September 2016 (Public)

G-scan & G-scan 2

VEHICLE COVERAGE LIST

EZDS

For more information, please email sales@e-zds.com, or call +82-70-7733-7775

GIT

INDEX

1 ACURA
2 ASIANTRUCK
3 AUDI-VW-SEAT-SKODA
4 BENZ
5 BMW
6 CHERY
7 CHEVROLET
8 CHRYSLER
9 CITROEN
10 CMC
11 DACIA
12 DAIHATSU
13 DODGE
14 FIAT-ALFA ROMEO-LANCIA
15 FORD AU
16 FORD EU
17 FORD USA
18 FUSO
19 GM DAEWOO
20 GM USA
21 GREATWALL
22 HINO
23 HOLDEN
24 HONDA
25 IKCO
26 INFINITI
27 ISUZU
28 JAGUAR
29 JEEP
30 LAND ROVER
31 LEXUS
32 LIFAN
33 LUXGEN
34 MAHINDRA
35 MARUTI
36 MAZDA
37 MINI
38 MITSUBISHI
39 NAZA
40 NISSAN
41 OPEL
42 PERODUA
43 PEUGEOT
44 PROTON
45 RENAULT
46 SAIPA
47 SPERANZA
48 SSANGYONG
49 SUBARU
50 SUZUKI
51 TATA
52 TOYOTA
53 UD
54 VAZGAZUAZ
55 VENIRAUTO
56 VOLVO

Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	ECU Reset	SCS Short Mode	ALL SENSORS	VSA SENSOR NEUTRAL POSITION MEMORIZATION	VSA SENS NEUTRAL POS MEM (Manual	Torque Sensor Learn	REWRITE KEYS	ALL KEYS LOST	REWRITE KEYS	ALL KEYS LOST	System Check	Number of Key	Key Type	Keyless Transmitter Registration	IQA Data Status	IQA Data Write	DPF Regeneration	DPF Differential Pressure Sensor Initial Learn	Reset Calculated PM Value	CRANK (CKP PATTERN CLEAR	CRANK (CKP PATTERN LEARNING	CRANK (CKP PATTERN CLEAR	CRANK (CKP PATTERN LEARNING	TP Position Check (TP learning Value Reset	FUEL PUMP ON TEST	ONE INJECTOR	ALL INJECTORS	A/C CLUTCH TEST	OPDS Initialization	Power Window Reset for Driver side	Power Window Reset for Passenger side	Power Window Reset for Left Rear	Power Window Reset for Right Rear	EGR test	Cruise Control Cancel History	ETCS (TAC TEST	FUEL PUMP OFF TEST	Shift Solenoid A Test	Shift Solenoid B Test
16PIN CONNECTOR	SYSTEM SEARCH																																													
16PIN CONNECTOR	Engine		V	V	V		V	V																			V	V	V	V	V	V	V	V	V						V	V	V	V		
16PIN CONNECTOR	Diesel		V		V		V	V														V	V	V	V	V									V											
16PIN CONNECTOR	AT/CVT		V	V	V		V	V																																					V	V
16PIN CONNECTOR	ABS(Antilocked Braking System)	ABS(Antilocked Braking System)	V		V	V	V																																							
16PIN CONNECTOR	ABS(Antilocked Braking System)	VSA(Vehicle Stability Assist)	V		V	V	V			V	V	V																																		
16PIN CONNECTOR	SRS Airbag		V		V		V																													V										
16PIN CONNECTOR	Immobilizer/One Push Start																																													
16PIN CONNECTOR	Immobilizer/One Push Start	PCU	V		V		V																																							
16PIN CONNECTOR	Immobilizer/One Push Start	Registration																																												
16PIN CONNECTOR	Immobilizer/One Push Start	Backup Unit	V		V		V																																							
16PIN CONNECTOR	Immobilizer/One Push Start	SLOT Control Unit	V		V		V																																							
16PIN CONNECTOR	Immobilizer/One Push Start	Control Unit	V		V		V																																							
16PIN CONNECTOR	Immobilizer/One Push Start													V	V	V	V	V	V	V	V																									
16PIN CONNECTOR	IMA		V				V																																							
16PIN CONNECTOR	ACM		V				V																																							
16PIN CONNECTOR	EPS		V		V		V						V																																	
16PIN CONNECTOR	SH-AWD		V		V		V																																							
16PIN CONNECTOR	VTM 4		V				V																																							
16PIN CONNECTOR	AWD		V		V		V																																							
16PIN CONNECTOR	City-Brake Active System		V		V		V																																							
16PIN CONNECTOR	Electronic Servo Brake System		V		V		V																																							
16PIN CONNECTOR	Acoustic Vehicle Alerting System		V		V		V																																							
16PIN CONNECTOR	CAN Gateway		V				V																																							
16PIN CONNECTOR	Integrated Driver Support System		V				V																																							
16PIN CONNECTOR	Active Damper		V																																											
16PIN CONNECTOR	POP-UP HOOD		V		V		V																																							
16PIN CONNECTOR	TPMS		V		V		V																																							
16PIN CONNECTOR	EVPS		V					V																																							
16PIN CONNECTOR	BODY	GAUGE	V		V		V																																							
16PIN CONNECTOR	BODY	LIGHTING	V		V	V																																								
16PIN CONNECTOR	BODY	DOOR LOCKS	V		V	V																																								
16PIN CONNECTOR	BODY	KEYLESS TRANSMITTER	V		V																																									
16PIN CONNECTOR	BODY	POWER WINDOWS	V		V																															V	V	V	V							
16PIN CONNECTOR	BODY	WIPER	V		V	V																																								
16PIN CONNECTOR	BODY	SECURITY	V		V																																									
16PIN CONNECTOR	BODY	HVAC/CLIMATE CONTROL	V		V																																									
16PIN CONNECTOR	BODY	POWER TRUNK	V		V	V																																								
16PIN CONNECTOR	BODY	POWER SEAT/MIRROR	V		V	V																																								

Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	ECU Reset	SCS Short Mode	ALL SENSORS	VSA SENSOR NEUTRAL POSITION MEMORIZATION	VSA SENS NEUTRAL POS MEM (Manual	Torque Sensor Learn	REWRITE KEYS	ALL KEYS LOST	REWRITE KEYS	ALL KEYS LOST	System Check	Number of Key	Key Type	Keyless Transmitter Registration	IQA Data Status	IQA Data Write	DPF Regeneration	DPF Differential Pressure Sensor Initial Learn	Reset Calculated PM Value	CRANK (CKP PATTERN CLEAR	CRANK (CKP PATTERN LEARNING	CRANK (CKP PATTERN CLEAR	CRANK (CKP PATTERN LEARNING	TP Position Check (TP learning Value Reset	FUEL PUMP ON TEST	ONE INJECTOR	ALL INJECTORS	A/C CLUTCH TEST	OPDS Initialization	Power Window Reset for Driver side	Power Window Reset for Passenger side	Power Window Reset for Left Rear	Power Window Reset for Right Rear	EGR test	Cruise Control Cancel History	ETCS (TAC TEST	FUEL PUMP OFF TEST	Shift Solenoid A Test	Shift Solenoid B Test
16PIN CONNECTOR	BODY	ADAPTIVE FRONT LIGHTING	V		V																																										
16PIN CONNECTOR	BODY	AUTO LIGHT LEVELING	V		V																																										
16PIN CONNECTOR	BODY	POWER TAIL GATE	V		V	V																																									
16PIN CONNECTOR	BODY	OnStar	V		V																																										
16PIN CONNECTOR	BODY	High Beam Support	V		V																																										
16PIN CONNECTOR	BODY	Active Cornering Light	V		V																																										
16PIN CONNECTOR	BODY	Parking Sensor	V		V																																										
16PIN CONNECTOR	BODY	HF LINK TEL	V		V																																										
16PIN CONNECTOR	BODY	Power Sliding Door	V		V	V																																									
16PIN CONNECTOR	SCS SHORT MODE								V																																						
3PIN CONNECTOR	SYSTEM SEARCH																																														
3PIN CONNECTOR	Engine		V		V		V	V																																							
3PIN CONNECTOR	AT		V		V		V	V																																							
3PIN CONNECTOR	CVT		V		V		V	V																																							
3PIN CONNECTOR	ABS(Antilocked Braking System)	ABS(Antilocked Braking System)	V		V	V	V																																								
3PIN CONNECTOR	ABS(Antilocked Braking System)	VSA(Vehicle Stability Assist)	V		V	V	V																																								
3PIN CONNECTOR	SRS Airbag		V		V																																										

Year	System 1	System 2	Shift Solenoid C Test	Shift Solenoid D Test	Shift Solenoid E Test	Pressure Test Assistance Mode	Shift Lock Solenoid Test	Clutch Pressure Control Solenoid Valve Control	Clutch Pressure Control (Linear Solenoid Valve A Test	Clutch Pressure Control (Linear Solenoid Valve B Test	Clutch Pressure Control (Linear Solenoid Valve C Test	Clutch Pressure Control (Linear Solenoid Valve D Test	Shift Solenoid Test	Acceleration Device Test	Clutch Coil Test	Differential Torque Calibration	YAW Rate/Lateral Acceleration Sensor Calibration	Steering Angle Sensor Calibration	SH-AWD Initialization	All Sensor Calibration	Seat Output Check	SWS Initialization	Inhibitor Solenoid	Shift Lock Solenoid Test	Start Clutch Status Data Clear	Start Clutch Status Feedback Learn	ACM Reset	VTC Test	EGR Test	Injector Test	Fuel Heater ON/OFF	ACG ON/OFF	Glow ON/OFF	MAF Sensor Learning Clear	A/F Sensor Learning Clear	ISV Forced Learning	Keyless Check	History Data	History Data Clear	Initialization	Service Reminder (USA	PAX Warning Reset (USA	ODS Initialization	Add A KEYLESS ACCESS Remote	Rewrite KEYLESS ACCESS Remotes	All KEYLESS ACCESS Remotes Lost
16PIN CONNECTOR	SYSTEM SEARCH																																														
16PIN CONNECTOR	Engine																											V	V																		
16PIN CONNECTOR	Diesel																													V	V	V	V	V	V	V											
16PIN CONNECTOR	AT/CVT		V	V	V	V	V	V	V	V	V	V											V	V	V	V																					
16PIN CONNECTOR	ABS(Antilocked Braking System)	ABS(Antilocked Braking System)																																													
16PIN CONNECTOR	ABS(Antilocked Braking System)	VSA(Vehicle Stability Assist)																																													
16PIN CONNECTOR	SRS Airbag																				V	V																						V			
16PIN CONNECTOR	Immobilizer/One Push Start																																														
16PIN CONNECTOR	Immobilizer/One Push Start	PCU																																													
16PIN CONNECTOR	Immobilizer/One Push Start	Registration																																											V	V	V
16PIN CONNECTOR	Immobilizer/One Push Start	Backup Unit																																													
16PIN CONNECTOR	Immobilizer/One Push Start	SLOT Control Unit																																													
16PIN CONNECTOR	Immobilizer/One Push Start	Control Unit																																													
16PIN CONNECTOR	Immobilizer/One Push Start																																														
16PIN CONNECTOR	IMA																																														
16PIN CONNECTOR	ACM																										V																				
16PIN CONNECTOR	EPS																																														
16PIN CONNECTOR	SH-AWD												V	V	V	V	V	V	V	V																											
16PIN CONNECTOR	VTM 4																																						V								
16PIN CONNECTOR	AWD																																														
16PIN CONNECTOR	City-Brake Active System																																														
16PIN CONNECTOR	Electronic Servo Brake System																																														
16PIN CONNECTOR	Acoustic Vehicle Alerting System																																														
16PIN CONNECTOR	CAN Gateway																																														
16PIN CONNECTOR	Integrated Driver Support System																																														
16PIN CONNECTOR	Active Damper																																														
16PIN CONNECTOR	POP-UP HOOD																																														
16PIN CONNECTOR	TPMS																																														
16PIN CONNECTOR	EVPS																																														
16PIN CONNECTOR	BODY	GAUGE																																													
16PIN CONNECTOR	BODY	LIGHTING																																													
16PIN CONNECTOR	BODY	DOOR LOCKS																																													
16PIN CONNECTOR	BODY	KEYLESS TRANSMITTER																																		V											
16PIN CONNECTOR	BODY	POWER WINDOWS																																													
16PIN CONNECTOR	BODY	WIPER																																													
16PIN CONNECTOR	BODY	SECURITY																																													
16PIN CONNECTOR	BODY	HVAC/CLIMATE CONTROL																																													
16PIN CONNECTOR	BODY	POWER TRUNK																																													
16PIN CONNECTOR	BODY	POWER SEAT/MIRROR																																													

Year	System 1	System 2	Shift Solenoid C Test	Shift Solenoid D Test	Shift Solenoid E Test	Pressure Test Assistance Mode	Shift Lock Solenoid Test	Clutch Pressure Control Solenoid Valve Control	Clutch Pressure Control (Linear Solenoid Valve A Test	Clutch Pressure Control (Linear Solenoid Valve B Test	Clutch Pressure Control (Linear Solenoid Valve C Test	Clutch Pressure Control (Linear Solenoid Valve D Test	Shift Solenoid Test	Acceleration Device Test	Clutch Coil Test	Differential Torque Calibration	YAW Rate/Lateral Acceleration Sensor Calibration	Steering Angle Sensor Calibration	SH-AWD Initialization	All Sensor Calibration	Seat Output Check	SWS Initialization	Inhibitor Solenoid	Shift Lock Solenoid Test	Start Clutch Status Data Clear	Start Clutch Status Feedback Learn	ACM Reset	VTC Test	EGR Test	Injector Test	Fuel Heater ON/OFF	ACG ON/OFF	Glow ON/OFF	MAF Sensor Learning Clear	A/F Sensor Learning Clear	ISV Forced Learning	Keyless Check	History Data	History Data Clear	Initialization	Service Reminder (USA	PAX Warning Reset (USA	ODS Initialization	Add A KEYLESS ACCESS Remote	Rewrite KEYLESS ACCESS Remotes	All KEYLESS ACCESS Remotes Lost
16PIN CONNECTOR	BODY	ADAPTIVE FRONT LIGHTING																																													
16PIN CONNECTOR	BODY	AUTO LIGHT LEVELING																																													
16PIN CONNECTOR	BODY	POWER TAIL GATE																																													
16PIN CONNECTOR	BODY	OnStar																																													
16PIN CONNECTOR	BODY	High Beam Support																																													
16PIN CONNECTOR	BODY	Active Cornering Light																																													
16PIN CONNECTOR	BODY	Parking Sensor																																													
16PIN CONNECTOR	BODY	HF LINK TEL																																													
16PIN CONNECTOR	BODY	Power Sliding Door																																													
16PIN CONNECTOR	SCS SHORT MODE																																														
3PIN CONNECTOR	SYSTEM SEARCH																																														
3PIN CONNECTOR	Engine																																														
3PIN CONNECTOR	AT																																														
3PIN CONNECTOR	CVT																																														
3PIN CONNECTOR	ABS(Antilocked Braking System)	ABS(Antilocked Braking System)																																													
3PIN CONNECTOR	ABS(Antilocked Braking System)	VSA(Vehicle Stability Assist)																																													
3PIN CONNECTOR	SRS Airbag																																														

Year	System 1	System 2	Self Check	System Check	Number of KEYLESS ACCESS Remotes)	Sensor ID Learning	VTEC TEST	Modulator Bleed	Front ACM Solenoid ON/OFF	Rear ACM Solenoid ON/OFF	Front/Rear ACM Solenoid ON/OFF	Warning Display Force Activation	Vehicle Level Position Calibration	Self Check	History Data	Functional Tests	Customize Rese	Air Bleeding	Longitudinal G Sensor Learning	Left Front Solenoid Test	Right Front Solenoid Test	Left Rear Solenoid Test	Right Rear Solenoid Test	Left Front VSA Test	Right Front VSA Test	Left Rear VSA Test	Right Rear VSA Test	Left Front CAS Regulator Valve Test	Right Front CAS Regulator Valve Test	Left Rear CAS Regulator Valve Test	Right Rear CAS Regulator Valve Test	System Information	Parameter Information	Motor Rotor Position Calibration	IPU Module Fan Drive Test	HVAC_Climate Control Unit Self Test	Idle Stop Starter Counter Check	Warning Indicators	ECU Clear	Cell Voltage Sensor Check	Initiator Operation Check	Sensor ID Learning	MA - EPS Control ON / OFF	Radar Aiming	Static Camera Aiming
16PIN CONNECTOR	SYSTEM SEARCH																																												
16PIN CONNECTOR	Engine						V																													V									
16PIN CONNECTOR	Diesel																																												
16PIN CONNECTOR	AT/CVT																																												
16PIN CONNECTOR	ABS(Antilocked Braking System)	ABS(Antilocked Braking System)																		V	V	V	V																						
16PIN CONNECTOR	ABS(Antilocked Braking System)	VSA(Vehicle Stability Assist)						V												V	V	V	V	V	V	V	V	V	V	V	V														
16PIN CONNECTOR	SRS Airbag																															V	V												
16PIN CONNECTOR	Immobilizer/One Push Start																																												
16PIN CONNECTOR	Immobilizer/One Push Start	PCU												V	V																														
16PIN CONNECTOR	Immobilizer/One Push Start	Registration																																											
16PIN CONNECTOR	Immobilizer/One Push Start	Backup Unit	V	V	V																																								
16PIN CONNECTOR	Immobilizer/One Push Start	SLOT Control Unit																																											
16PIN CONNECTOR	Immobilizer/One Push Start	Control Unit																																											
16PIN CONNECTOR	Immobilizer/One Push Start																																												
16PIN CONNECTOR	IMA																																												
16PIN CONNECTOR	ACM								V	V	V																																		
16PIN CONNECTOR	EPS																																									V			
16PIN CONNECTOR	SH-AWD																																												
16PIN CONNECTOR	VTM 4																																												
16PIN CONNECTOR	AWD																	V	V																										
16PIN CONNECTOR	City-Brake Active System																																												
16PIN CONNECTOR	Electronic Servo Brake System																																												
16PIN CONNECTOR	Acoustic Vehicle Alerting System																																												
16PIN CONNECTOR	CAN Gateway																																												
16PIN CONNECTOR	Integrated Driver Support System																																											V	V
16PIN CONNECTOR	Active Damper																																												
16PIN CONNECTOR	POP-UP HOOD											V	V																																
16PIN CONNECTOR	TPMS					V																															V			V	V				
16PIN CONNECTOR	EVPS																																												
16PIN CONNECTOR	BODY	GAUGE														V	V																												
16PIN CONNECTOR	BODY	LIGHTING																																											
16PIN CONNECTOR	BODY	DOOR LOCKS																																											
16PIN CONNECTOR	BODY	KEYLESS TRANSMITTER																																											
16PIN CONNECTOR	BODY	POWER WINDOWS																																											
16PIN CONNECTOR	BODY	WIPER																																											
16PIN CONNECTOR	BODY	SECURITY																																											
16PIN CONNECTOR	BODY	HVAC/CLIMATE CONTROL																																	V										
16PIN CONNECTOR	BODY	POWER TRUNK																																											
16PIN CONNECTOR	BODY	POWER SEAT/MIRROR																																											

Year	System 1	System 2	Self Check	System Check	Number of KEYLESS ACCESS Remotes)	Sensor ID Learning	VTEC TEST	Modulator Bleed	Front ACM Solenoid ON/OFF	Rear ACM Solenoid ON/OFF	Front/Rear ACM Solenoid ON/OFF	Warning Display Force Activation	Vehicle Level Position Calibration	Self Check	History Data	Functional Tests	Customize Rese	Air Bleeding	Longitudinal G Sensor Learning	Left Front Solenoid Test	Right Front Solenoid Test	Left Rear Solenoid Test	Right Rear Solenoid Test	Left Front VSA Test	Right Front VSA Test	Left Rear VSA Test	Right Rear VSA Test	Left Front CAS Regulator Valve Test	Right Front CAS Regulator Valve Test	Left Rear CAS Regulator Valve Test	Right Rear CAS Regulator Valve Test	System Information	Parameter Information	Motor Rotor Position Calibration	IPU Module Fan Drive Test	HVAC_Climate Control Unit Self Test	Idle Stop Starter Counter Check	Warning Indicators	ECU Clear	Cell Voltage Sensor Check	Initiator Operation Check	Sensor ID Learning	MA - EPS Control ON / OFF	Radar Aiming	Static Camera Aiming
16PIN CONNECTOR	BODY	ADAPTIVE FRONT LIGHTING																																											
16PIN CONNECTOR	BODY	AUTO LIGHT LEVELING																																											
16PIN CONNECTOR	BODY	POWER TAIL GATE																																											
16PIN CONNECTOR	BODY	OnStar																																											
16PIN CONNECTOR	BODY	High Beam Support																																											
16PIN CONNECTOR	BODY	Active Cornering Light																																											
16PIN CONNECTOR	BODY	Parking Sensor																																											
16PIN CONNECTOR	BODY	HF LINK TEL																																											
16PIN CONNECTOR	BODY	Power Sliding Door																																											
16PIN CONNECTOR	SCS SHORT MODE																																												
3PIN CONNECTOR	SYSTEM SEARCH																																												
3PIN CONNECTOR	Engine																																												
3PIN CONNECTOR	AT																																												
3PIN CONNECTOR	CVT																																												
3PIN CONNECTOR	ABS(Antilocked Braking System)	ABS(Antilocked Braking System)																																											
3PIN CONNECTOR	ABS(Antilocked Braking System)	VSA(Vehicle Stability Assist)																																											
3PIN CONNECTOR	SRS Airbag																																												

Area	Maker	Vehicle	System 1	Connector	System 2	DTC	CURRENT DATA	ACTUATION TEST	ECU INFORMATION	Idling micro-adjust
ASIAN	SINO	HOWO	T5G340	MC07	Engine	V	V		V	
ASIAN	THACO	TOWN	TB82S	WEICHAI III(WP5)	Engine	V	V	V	V	V
ASIAN	THACO	TOWN	TB95S	WEICHAI III(WP7)	Engine	V	V	V	V	V
ASIAN	THACO	CITY	TB94CT(B60)	WEICHAI III(WP6)	Engine	V	V	V	V	V
ASIAN	THACO	CITY	TB115CT(B80)	WEICHAI III(WP7)	Engine	V	V	V	V	V
ASIAN	THACO	UNIVERSE	TB120LS	WEICHAI III(WP12)	Engine	V	V	V	V	V
ASIAN	THACO	UNIVERSE	TB120S	WEICHAI III(WP12)	Engine	V	V	V	V	V
ASIAN	THACO	MOBIHOME	TB120SL	WEICHAI III(WP12)	Engine	V	V	V	V	V
ASIAN	THACO	AUMAN	FV375	WEICHAI III(WP12)	Engine	V	V	V	V	V

Vehicle	Group	System	DTC Analysis	Data Analysis	Read Measuring Value Block	Actuation Test	System Information	Quick Search (CAN only)	Quick Search (CAN via UDS only)	Basic Setting	Adaptation Control	Long Adaptation	Long Coding	Recode Module	Security Access	Coding II	Service Reminder Reset	Instrument Cluster Language	Coding	ESI Resetting	Read Independent Value	Code Control	Login Control	Instruments Option Coding	EPB Pad Exchange for Audi A8	EPB Pad Exchange except Audi A8	Abbreviations	Service interval reset	Service Reset - Kilometers	Service Reset - Days
General	Maintenance	Quick Search(CAN only)						V	V																					
General	Maintenance	17 Oil Service(ESI/SRI Reset)	V	V	V	V	V			V	V	V	V	V	V	V	V	V	V	V	V	V	V	V						
General	Maintenance	53 Brake Pads Exchange(EPB)	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V		V	V				
General	Maintenance	Technical Information					V																				V			
General	Common	01 Engine Electronics	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Common	02 Transmission Electronics	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Common	03 Brake Electronics	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Common	08 Auto HVAC	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Common	09 Electronic Central Electrics	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Common	15 Airbag	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Common	16 Steering Wheel Electronics	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Common	17 Instrument Cluster	V	V	V	V	V			V	V	V	V	V	V	V	V	V	V	V	V	V	V	V						
General	Common	18 Auxiliary Heater	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Common	19 CAN Gateway	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Common	22 4WD Electronics	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Common	25 Immobilizer	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Common	35 Central Locking	V		V	V	V			V	V			V	V	V					V	V	V							
General	Common	37 Navigation	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Common	45 Interior Monitoring	V		V	V	V			V	V			V	V	V					V	V	V							
General	Common	46 Central Module Convenience System	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Common	55 Headlight Range Control	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Common	56 Radio	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Powertrain	01 Engine Electronics	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Powertrain	11 Engine Electronics 2	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Powertrain	21 Engine Electronics 3	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Powertrain	31 Engine Electronics Conjunction	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Powertrain	41 Diesel Pump Electronics	V		V	V	V			V	V			V	V	V					V	V	V							
General	Powertrain	51 Electric Drive	V		V	V	V			V	V			V	V	V					V	V	V							
General	Powertrain	61 Battery Regulation	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Powertrain	71 Battery Charger	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Powertrain	02 Transmission Electronics	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Powertrain	12 Clutch Electronics	V		V	V	V			V	V			V	V	V					V	V	V							
General	Powertrain	13 Distance Regulation	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Powertrain	58 Auxiliary Fuel Tank	V		V	V	V			V	V			V	V	V					V	V	V							
General	Powertrain	81 Gear Shift	V				V			V					V				V											
General	Chassis	22 4WD Electronics	V		V	V	V			V	V	V	V	V	V	V														
General	Common	22 4WD Electronics	V	V		V	V			V	V				V				V											
General	Chassis	22 4WD Electronics	V		V	V	V			V	V			V	V	V					V	V	V							
General	Chassis	03 Brake Electronics	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Chassis	23 Brake Booster	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Chassis	43 Brake Booster Assistance	V		V	V	V			V	V			V	V	V					V	V	V							

Vehicle	Group	System	DTC Analysis	Data Analysis	Read Measuring Value Block	Actuation Test	System Information	Quick Search (CAN only)	Quick Search (CAN via UDS only)	Basic Setting	Adaptation Control	Long Adaptation	Long Coding	Recode Module	Security Access	Coding II	Service Reminder Reset	Instrument Cluster Language	Coding	ESI Resetting	Read Independent Value	Code Control	Login Control	Instruments Option Coding	EPB Pad Exchange for Audi A8	EPB Pad Exchange except Audi A8	Abbreviations	Service interval reset	Service Reset - Kilometers	Service Reset - Days
General	Chassis	53 Parking Brake	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V		V	V				
General	Chassis	04 Steering Angle	V	V		V	V			V					V				V											
General	Chassis	14 Suspension Electronics	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Chassis	24 Anti Slip/Traction Control	V		V	V	V			V	V			V	V	V					V	V	V							
General	Chassis	34 Self Leveling Suspension	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Chassis	64 Stabilizers	V		V	V	V			V	V			V	V	V					V	V	V							
General	Chassis	65 Tire Pressure Monitoring	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Chassis	59 Towing Protection	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Chassis	69 Trailer Function	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Chassis	1B Active Steering	V		V	V	V			V	V	V	V	V	V	V														
General	Chassis	3C Lane Change Assistant	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Chassis	4C Tire Pressure 2	V		V	V	V			V	V	V	V	V	V	V														
General	Chassis	5C Lane Maintenance System	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Chassis	8C Battery Energy Control Module	V	V		V	V			V	V				V				V											
General	Body	32 Locking Electronics	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Body	42 Door Electronics-Driver	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Body	52 Door Electronics-Passenger	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Body	62 Door Electronics-Left Rear	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Body	72 Door Electronics-Right Rear	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Body	63 Boarding Assistance-Driver	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Body	73 Boarding Assistance-Passenger	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Body	44 Steering Assistance	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Body	54 Rear Spoiler	V		V	V	V			V	V			V	V	V					V	V	V							
General	Body	15 Airbag	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Body	25 Immobilizer	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Body	35 Central Locking	V		V	V	V			V	V			V	V	V					V	V	V							
General	Body	1D Driver Identification	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Body	45 Interior Monitoring	V		V	V	V			V	V			V	V	V					V	V	V							
General	Body	55 Headlight Range Control	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Body	16 Steering Wheel Electronics	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Body	26 Electronic Roof Controls	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Body	46 Central Module Convenience System	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Body	38 Roof Electronics	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Body	68 Wiper Electronics	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Body	78 Sliding Door-Right	V		V	V	V			V	V			V	V	V					V	V	V							
General	Body	0D Sliding Door-Left	V		V	V	V			V	V			V	V	V					V	V	V							
General	Body	6D Trunk Electronics	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Body	09 Electronic Central Electrics	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Body	4F Central Electronics 2	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Body	29 Light Control-Left	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Body	39 Light Control-Right	V		V	V	V			V	V	V	V	V	V	V					V	V	V							

Vehicle	Group	System	DTC Analysis	Data Analysis	Read Measuring Value Block	Actuation Test	System Information	Quick Search (CAN only)	Quick Search (CAN via UDS only)	Basic Setting	Adaptation Control	Long Adaptation	Long Coding	Recode Module	Security Access	Coding II	Service Reminder Reset	Instrument Cluster Language	Coding	ESI Resetting	Read Independent Value	Code Control	Login Control	Instruments Option Coding	EPB Pad Exchange for Audi A8	EPB Pad Exchange except Audi A8	Abbreviations	Service interval reset	Service Reset - Kilometers	Service Reset - Days
General	Body	49 Automatic Lighting Switch	V		V	V	V			V	V			V	V	V					V	V	V							
General	Body	89 Multicont. Seat Pass.	V				V			V					V				V											
General	Body	10 Park/Steer Assist	V	V	V	V	V			V	V	V	V	V	V	V			V											
General	Body	20 High Beam Assist	V		V	V	V			V	V	V	V	V	V	V														
General	Body	3B Sensor Electronics	V				V			V					V				V											
General	Body	5F Information Electronics	V	V	V	V	V			V	V	V	V	V	V	V			V											
General	Body	6F Control Convenience 2	V	V	V	V	V			V	V	V	V	V	V	V			V											
General	Body	84 Night Vision	V	V		V	V			V					V				V											
General	Body	85 On Board Camera	V				V			V					V				V											
General	Body	8B Adaptive Cruise 2	V	V		V	V			V					V				V											
General	Body	8E Image Processing	V				V			V					V				V											
General	Body	8F Pretens Front Left	V	V		V	V			V					V				V											
General	Body	2B Steering Column Lock	V	V		V	V			V					V				V											
General	Body	AC Reductant Control	V				V			V					V				V											
General	Body	90 Pretens Front Right	V	V		V	V			V					V				V											
General	Body	A5 Front sensors Driver Assistance	V	V		V	V			V					V															
General	Information and Communication	75 Telematics	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	1C Vehicle Position Detection	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	56 Radio	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	76 Parking Aid	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	2D Voice Amplification	V		V	V	V			V	V			V	V	V					V	V	V							
General	Information and Communication	7E Instrument Cluster Display Unit	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	07 Display Control Unit	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	17 Instrument Cluster	V	V	V	V	V			V	V	V	V	V	V	V	V	V	V	V	V	V	V	V						
General	Information and Communication	27 Display Control Unit-Rear	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	4E Display Control Unit-Rear Right	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	5E Display Control Unit-Rear Left	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	37 Navigation	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Information and Communication	47 Sound System	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Information and Communication	57 TV Tuner	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	67 Voice Control	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	77 Telephone	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Information and Communication	6E Roof Display/Control Head	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	19 CAN Gateway	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Information and Communication	0F Radio Tuner-Digital	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	1F Radio Tuner-Satellite	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	2F TV Tuner-Digital	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	6C Back-up Camera	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Information and Communication	3D Special Function	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	4D Data Transfer	V		V	V	V			V	V			V	V	V					V	V	V							
General	Information and Communication	5D Operations	V		V	V	V			V	V	V	V	V	V	V					V	V	V							

Vehicle	Group	System	DTC Analysis	Data Analysis	Read Measuring Value Block	Actuation Test	System Information	Quick Search (CAN only)	Quick Search (CAN via UDS only)	Basic Setting	Adaptation Control	Long Adaptation	Long Coding	Recode Module	Security Access	Coding II	Service Reminder Reset	Instrument Cluster Language	Coding	ESI Resetting	Read Independent Value	Code Control	Login Control	Instruments Option Coding	EPB Pad Exchange for Audi A8	EPB Pad Exchange except Audi A8	Abbreviations	Service interval reset	Service Reset - Kilometers	Service Reset - Days
General	Information and Communication	0E Media Player 1	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	1E Media Player 2	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	2E Media Player 3	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	3E Media Player 4	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Information and Communication	A9 Struct. Borne Sound	V	V						V	V																			
General	Seats and Doors	05 Access and Start Permission	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Seats and Doors	06 Seat Adjustment-Passenger	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Seats and Doors	36 Seat Adjustment-Driver	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Seats and Doors	66 Seat Adjustment-Rear Right	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Seats and Doors	48 Seat Adjustment-Rear Left	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Seats and Doors	88 Multicont Seat Driver	V				V			V					V				V											
General	Seats and Doors	8A Multicont Seat Rear DS	V				V			V					V				V											
General	Seats and Doors	8D Multicont Seat Rear PS	V				V			V					V				V											
General	Air Conditioning	08 Auto HVAC	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Air Conditioning	18 Auxiliary Heater	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
General	Air Conditioning	28 Climate Control Unit Rear	V	V	V	V	V			V	V	V	V	V	V	V			V		V	V	V							
General	Air Conditioning	7D Auxiliary Heater	V		V	V	V			V	V	V	V	V	V	V					V	V	V							
CrafterLT3	Maintenance	96-Service reset	V	V			V																					V	V	V
CrafterLT3	Common	91-Engine	V		V	V	V			V	V			V	V	V														
CrafterLT3	Common	92-Transmission	V				V																							
CrafterLT3	Common	93-Immo	V		V		V								V															
CrafterLT3	Common	94-Airbag	V				V																							
CrafterLT3	Common	95-ESP	V	V			V																							
CrafterLT3	Common	96-Instruments	V	V			V																					V	V	V
CrafterLT3	Common	99-Ign. Switch	V				V																							
CrafterLT3	Common	9A-Central Locks	V		V		V				V				V															
CrafterLT3	Common	9B-Driver Door	V	V			V																							
CrafterLT3	Common	9C-HVAC	V	V			V																							
CrafterLT3	Common	A0-Radio	V				V																							
CrafterLT3	Common	B1-Upper Console	V	V			V																							
CrafterLT3	Common	B4-Central Elec.	V	V			V																							
CrafterLT3	Common	B5-Special Function	V				V																							
CrafterLT3	Common	B6-Steering Wheel	V	V			V																							

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
A-CLASS	68		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V																												
A-CLASS	68		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
A-CLASS	68		Drive	ESM - Electronic selector module	V	V	V	V	V																												
A-CLASS	68		Drive	ACS - Automatic clutch system	V	V			V																												
A-CLASS	68		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
A-CLASS	168		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
A-CLASS	168		Body	LCP/HBF - Lower/Rear control panel	V	V			V																												
A-CLASS	168		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V	V	V																												
A-CLASS	168		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
A-CLASS	168		Body	AB - Airbag	V	V	V		V																												
A-CLASS	168		Information	PTS - Parktronic system	V	V	V	V	V																												
A-CLASS	168		Information	IC - Instrument cluster	V	V	V	V	V																		V										
A-CLASS	168		Information	AUDIO/COMAND	V	V		V	V																												
A-CLASS	168		Information	APS - Auto pilot system	V	V			V																												
A-CLASS	168		Seat/Door	DCM-RR - Door control module rear right	V	V		V	V																												
A-CLASS	168		Seat/Door	DCM-RL - Door control module rear left	V	V		V	V																												
A-CLASS	168		Seat/Door	DCM-FR - Door control module front right	V	V		V	V																												
A-CLASS	168		Seat/Door	DCM-FL - Door control module front left	V	V		V	V																												
A-CLASS	168		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
A-CLASS	168		Air Conditioning	HB - Heater booster	V	V	V	V	V																												
A-CLASS	168		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
A-CLASS	169		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V					V						V							V						V
A-CLASS	169		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
A-CLASS	169		Drive	ESM - Electronic selector module	V	V	V	V	V																												
A-CLASS	169		Drive	BSA - Belt-driven starter/alternator	V	V			V																												
A-CLASS	169		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
A-CLASS	169		Chassis	ES - Electrical power steering	V	V	V		V																												
A-CLASS	169		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
A-CLASS	169		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V																												
A-CLASS	169		Body	OCP - Overhead control panel	V	V	V	V	V																												
A-CLASS	169		Body	Multifunction control unit	V	V	V	V	V																												
A-CLASS	169		Body	Headlamp-R - Headlamp control unit	V	V	V		V																												
A-CLASS	169		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
A-CLASS	169		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
A-CLASS	169		Body	CGW - Central gateway	V	V			V																												
A-CLASS	169		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
A-CLASS	169		Body	AHE - Trailer recognition	V	V	V	V	V																												
A-CLASS	169		Body	AB - Airbag	V	V	V		V																												
A-CLASS	169		Information	SOUND - Sound system	V	V	V	V	V																												
A-CLASS	169		Information	PTS - Parktronic system	V	V	V	V	V																												
A-CLASS	169		Information	MIF/UCI - Media interface	V	V	V		V																												
A-CLASS	169		Information	IC - Instrument cluster	V	V	V	V	V																												
A-CLASS	169		Information	DAB/SDAR - Digital/Satellite radio	V	V	V		V																												
A-CLASS	169		Information	CTEL/TEL - Cellular/Mobile telephone	V	V	V		V																												
A-CLASS	169		Information	AUDIO/COMAND	V	V	V	V	V																												
A-CLASS	169		Information	ASSYST PLUS - PLUS Active Service System	V	V	V		V																												
A-CLASS	169		Information	ASSYST Active Service System	V	V	V		V																										V		
A-CLASS	169		Information	AGW - Audio gateway	V	V	V	V	V																												
A-CLASS	169		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
A-CLASS	169		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
A-CLASS	169		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
A-CLASS	169		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
A-CLASS	169		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
A-CLASS	176		Drive	VG - Transfer case	V	V			V																												
A-CLASS	176		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
A-CLASS	176		Drive	ETC - Electronic transmission control	V	V	V		V												V																
A-CLASS	176		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
A-CLASS	176		Drive	DTR - Distronic	V	V	V		V																												
A-CLASS	176		Drive	DSI - Direct select interface	V	V	V	V	V																												
A-CLASS	176		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
A-CLASS	176		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
A-CLASS	176		Chassis	ES - Electrical power steering	V	V	V		V																												
A-CLASS	176		Chassis	EFB - Electric parking brake	V	V	V		V																												
A-CLASS	176		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
A-CLASS	176		Body	SG-AWF - Collision prevention assist	V	V	V		V																												
A-CLASS	176		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
A-CLASS	176		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
A-CLASS	176		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
A-CLASS	176		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
A-CLASS	176		Body	Multifunction control unit	V	V	V	V	V																												
A-CLASS	176		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
A-CLASS	176		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
A-CLASS	176		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
A-CLASS	176		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
A-CLASS	176		Body	AHE - Trailer recognition	V	V	V	V	V																												
A-CLASS	176		Body	AB - Airbag	V	V	V		V																												
A-CLASS	176		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
A-CLASS	176		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
A-CLASS	176		Information	TV - TV tuner	V	V	V		V																												
A-CLASS	176		Information	SOUND - Sound system	V	V	V	V	V																												
A-CLASS	176		Information	RFK - Backup camera	V	V	V	V	V																												
A-CLASS	176		Information	MFK - Multifunction camera	V	V	V	V	V																												
A-CLASS	176		Information	PTS - Parktronic system	V	V	V	V	V																												
A-CLASS	176		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
A-CLASS	176		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
A-CLASS	176		Information	NAV - Navigation module	V	V	V	V	V																												
A-CLASS	176		Information	MIF/UCI - Media interface	V	V	V		V																												
A-CLASS	176		Information	IC - Instrument cluster	V	V	V	V	V																												
A-CLASS	176		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
A-CLASS	176		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
A-CLASS	176		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
A-CLASS	176		Information	AUDIO/COMAND	V	V	V	V	V																												
A-CLASS	176		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
A-CLASS	176		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
A-CLASS	176		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
A-CLASS	176		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
A-CLASS	176		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
A-CLASS	176		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V		V																												
A-CLASS	176		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
B-CLASS	245		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V											V						V							
B-CLASS	245		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
B-CLASS	245		Drive	ESM - Electronic selector module	V	V	V	V	V																												
B-CLASS	245		Drive	Hydrogen tank control unit	V	V			V																												
B-CLASS	245		Drive	High-temperature coolant pump control unit	V	V			V																												
B-CLASS	245		Drive	Fuel cell control unit	V	V			V																												
B-CLASS	245		Drive	Electric drive control unit	V	V			V																												
B-CLASS	245		Drive	Compressed Natural Gas Control Module	V	V			V																												
B-CLASS	245		Drive	BSA - Belt-driven starter/alternator	V	V			V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
B-CLASS	245		Drive	VECU - Power monitoring control unit	V	V			V																												
B-CLASS	245		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
B-CLASS	245		Chassis	ES - Electrical power steering	V	V	V		V																												
B-CLASS	245		Chassis	VP - Vacuum pump brake booster	V	V	V	V	V																												
B-CLASS	245		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
B-CLASS	245		Body	WSS - Weight sensing system	V	V	V		V																												
B-CLASS	245		Body	SG-DDW - DC/DC converter control unit	V	V			V																												
B-CLASS	245		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
B-CLASS	245		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V																												
B-CLASS	245		Body	OCP - Overhead control panel	V	V	V	V	V																												
B-CLASS	245		Body	Multifunction control unit	V	V	V	V	V																												
B-CLASS	245		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
B-CLASS	245		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
B-CLASS	245		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
B-CLASS	245		Body	CGW - Central gateway	V	V			V																												
B-CLASS	245		Body	BNS/BMS - Battery sensor	V	V			V																												
B-CLASS	245		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V	V	V	V																												
B-CLASS	245		Body	AHE - Trailer recognition	V	V	V	V	V																												
B-CLASS	245		Body	AB - Airbag	V	V	V		V																												
B-CLASS	245		Information	SOUND - Sound system	V	V	V	V	V																												
B-CLASS	245		Information	PTS - Parktronic system	V	V	V	V	V																												
B-CLASS	245		Information	NAV - Navigation module	V	V			V																												
B-CLASS	245		Information	MIF/UCI - Media interface	V	V	V		V																												
B-CLASS	245		Information	IC - Instrument cluster	V	V	V	V	V																												
B-CLASS	245		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
B-CLASS	245		Information	DAB/SDAR - Digital/Satellite radio	V	V	V		V																												
B-CLASS	245		Information	CTEL/TEL - Cellular/Mobile telephone	V	V	V		V																												
B-CLASS	245		Information	CM - Compass module	V	V	V		V																												
B-CLASS	245		Information	AUDIO/COMAND	V	V	V	V	V																												
B-CLASS	245		Information	ASSYST PLUS - PLUS Active Service System	V	V	V		V																												
B-CLASS	245		Information	ASSYST Active Service System	V	V	V		V																										V		
B-CLASS	245		Information	AGW - Audio gateway	V	V	V	V	V																												
B-CLASS	245		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
B-CLASS	245		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
B-CLASS	245		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
B-CLASS	245		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
B-CLASS	245		Air Conditioning	EKMK - Electric refrigerant compressor	V	V	V		V																												
B-CLASS	245		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
B-CLASS	246		Drive	Compressed Natural Gas Control Module	V	V			V																												
B-CLASS	246		Drive	VG - Transfer case	V	V			V																												
B-CLASS	246		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
B-CLASS	246		Drive	ETC - Electronic transmission control	V	V	V		V												V																
B-CLASS	246		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
B-CLASS	246		Drive	DTR - Distronic	V	V	V		V																												
B-CLASS	246		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
B-CLASS	246		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
B-CLASS	246		Chassis	ES - Electrical power steering	V	V	V		V																												
B-CLASS	246		Chassis	EFB - Electric parking brake	V	V	V		V																												
B-CLASS	246		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
B-CLASS	246		Body	BNS/BMS - Battery sensor	V	V			V																												
B-CLASS	246		Body	SG-AWF - Collision prevention assist	V	V	V		V																												
B-CLASS	246		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
B-CLASS	246		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
B-CLASS	246		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
B-CLASS	246		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
B-CLASS	246		Body	Multifunction control unit	V	V	V	V	V																												
B-CLASS	246		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
B-CLASS	246		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
B-CLASS	246		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
B-CLASS	246		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
B-CLASS	246		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
B-CLASS	246		Body	AHE - Trailer recognition	V	V	V	V	V																												
B-CLASS	246		Body	AB - Airbag	V	V	V		V																												
B-CLASS	246		Information	Sound generator for exhaust system	V	V			V																												
B-CLASS	246		Information	Head-up display	V	V			V																												
B-CLASS	246		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
B-CLASS	246		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
B-CLASS	246		Information	TV - TV tuner	V	V	V		V																												
B-CLASS	246		Information	SOUND - Sound system	V	V	V	V	V																												
B-CLASS	246		Information	RFK - Backup camera	V	V	V	V	V																												
B-CLASS	246		Information	MFK - Multifunction camera	V	V	V	V	V																												
B-CLASS	246		Information	PTS - Parktronic system	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
B-CLASS	246		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
B-CLASS	246		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
B-CLASS	246		Information	NAV - Navigation module	V	V	V	V	V																												
B-CLASS	246		Information	MIF/UCI - Media interface	V	V	V		V																												
B-CLASS	246		Information	IC - Instrument cluster	V	V	V	V	V																												
B-CLASS	246		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
B-CLASS	246		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
B-CLASS	246		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
B-CLASS	246		Information	AUDIO/COMAND	V	V	V	V	V																												
B-CLASS	246		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
B-CLASS	246		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
B-CLASS	246		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
B-CLASS	246		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
B-CLASS	246		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
B-CLASS	246		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V		V																												
B-CLASS	246		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
C-CLASS	202		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V																								
C-CLASS	202		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
C-CLASS	202		Drive	ESM - Electronic selector module	V	V	V	V	V																												
C-CLASS	202		Chassis	PSE - Pneumatic system equipment	V				V																												
C-CLASS	202		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
C-CLASS	202		Chassis	VP - Vacuum pump brake booster	V	V	V	V	V																												
C-CLASS	202		Chassis	BAS - Brake assist	V	V	V		V																												
C-CLASS	202		Body	LCP/HBF - Lower/Rear control panel	V		V	V	V																												
C-CLASS	202		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V				V																												
C-CLASS	202		Body	EZS/EIS - Electronic ignition lock	V		V		V																												
C-CLASS	202		Body	OCP - Overhead control panel	V		V		V																												
C-CLASS	202		Body	AB - Airbag	V		V		V																												
C-CLASS	202		Information	PTS - Parktronic system	V	V	V	V	V																												
C-CLASS	202		Information	NAV - Navigation module	V	V			V																												
C-CLASS	202		Information	IC - Instrument cluster	V	V	V	V	V																			V									
C-CLASS	202		Information	DTA - Mbrace or TELEAID/GPS Box	V	V		V	V													V															
C-CLASS	202		Information	AUDIO/COMAND	V	V		V	V																												
C-CLASS	202		Information	APS - Auto pilot system	V	V			V																												
C-CLASS	202		Seat/Door	DCM-FR - Door control module front right	V				V																												
C-CLASS	202		Seat/Door	DCM-FL - Door control module front left	V				V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
C-CLASS	202		Seat/Door	DCM-RR - Door control module rear right	V				V																												
C-CLASS	202		Seat/Door	DCM-RL - Door control module rear left	V				V																												
C-CLASS	202		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
C-CLASS	202		Air Conditioning	HB - Heater booster	V	V	V	V	V																												
C-CLASS	202		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
C-CLASS	203		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V							V				V		V					V							
C-CLASS	203		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
C-CLASS	203		Drive	ESM - Electronic selector module	V	V	V	V	V																												
C-CLASS	203		Drive	DTR - Distronic	V	V	V		V																												
C-CLASS	203		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
C-CLASS	203		Chassis	VP - Vacuum pump brake booster	V	V	V	V	V																												
C-CLASS	203		Chassis	BAS - Brake assist	V	V	V		V																												
C-CLASS	203		Body	WSS - Weight sensing system	V	V	V		V																												
C-CLASS	203		Body	UCP - Upper control panel	V	V	V	V	V																												
C-CLASS	203		Body	System diagnosis	V	V			V																												
C-CLASS	203		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
C-CLASS	203		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
C-CLASS	203		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V																												
C-CLASS	203		Body	OCP - Overhead control panel	V	V	V	V	V																												
C-CLASS	203		Body	Multifunction control unit	V	V	V	V	V																												
C-CLASS	203		Body	LCP/HBF - Lower/Rear control panel	V	V	V	V	V																												
C-CLASS	203		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
C-CLASS	203		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
C-CLASS	203		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
C-CLASS	203		Body	CGW - Central gateway	V	V			V																												
C-CLASS	203		Body	AHE - Trailer recognition	V	V	V	V	V																												
C-CLASS	203		Body	AB - Airbag	V	V	V		V																												
C-CLASS	203		Information	TV - TV tuner	V	V		V	V																												
C-CLASS	203		Information	SOUND - Sound system	V	V	V	V	V																												
C-CLASS	203		Information	PTS - Parktronic system	V	V	V	V	V																												
C-CLASS	203		Information	NAV - Navigation module	V	V			V																												
C-CLASS	203		Information	MIF/UCI - Media interface	V	V	V		V																												
C-CLASS	203		Information	IC - Instrument cluster	V	V	V	V	V																												
C-CLASS	203		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V	V	V													V															
C-CLASS	203		Information	DAB/SDAR - Digital/Satellite radio	V	V	V		V																												
C-CLASS	203		Information	CTEL/TEL - Cellular/Mobile telephone	V	V	V		V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
C-CLASS	203		Information	AUDIO/COMAND	V	V	V	V	V																												
C-CLASS	203		Information	AGW - Audio gateway	V	V	V	V	V																												
C-CLASS	203		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
C-CLASS	203		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
C-CLASS	203		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
C-CLASS	203		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
C-CLASS	203		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
C-CLASS	203		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
C-CLASS	203		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
C-CLASS	203		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
C-CLASS	204		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V					V						V							V							V
C-CLASS	204		Drive	ETC - Electronic transmission control	V	V	V	V	V												V																
C-CLASS	204		Drive	ESM - Electronic selector module	V	V	V	V	V																												
C-CLASS	204		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
C-CLASS	204		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
C-CLASS	204		Drive	FSCU-R - Control unit fuel pump	V	V	V		V																												
C-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
C-CLASS	204		Drive	DTR - Distronic	V	V	V		V																												
C-CLASS	204		Drive	AMG DRIVE UNIT	V	V	V	V	V																												
C-CLASS	204		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
C-CLASS	204		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
C-CLASS	204		Chassis	Suspension	V	V	V	V	V																												
C-CLASS	204		Chassis	ES - Electrical power steering	V	V	V		V																												
C-CLASS	204		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
C-CLASS	204		Body	WSS - Weight sensing system	V	V	V		V																												
C-CLASS	204		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
C-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
C-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
C-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
C-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
C-CLASS	204		Body	OCP - Overhead control panel	V	V	V	V	V																												
C-CLASS	204		Body	Multifunction control unit	V	V	V	V	V																												
C-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
C-CLASS	204		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
C-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
C-CLASS	204		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
C-CLASS	204		Body	CGW - Central gateway	V	V	V		V																												
C-CLASS	204		Body	AHE - Trailer recognition	V	V	V	V	V																												
C-CLASS	204		Body	AB - Airbag	V	V	V		V																												
C-CLASS	204		Information	Head-up display	V	V			V																												
C-CLASS	204		Information	AVE-H - Rear audio video unit	V	V			V																												
C-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
C-CLASS	204		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
C-CLASS	204		Information	TV - TV tuner	V	V	V		V																												
C-CLASS	204		Information	Sound generator for exhaust system	V	V	V		V																												
C-CLASS	204		Information	SOUND - Sound system	V	V	V	V	V																												
C-CLASS	204		Information	SGR - Radar sensors control unit	V	V	V		V																												
C-CLASS	204		Information	360' - Camera	V	V	V		V																												
C-CLASS	204		Information	MFK - Multifunction camera	V	V	V	V	V																												
C-CLASS	204		Information	RFK - Backup camera	V	V	V	V	V																												
C-CLASS	204		Information	PTS - Parktronic system	V	V	V	V	V																												
C-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
C-CLASS	204		Information	NBR-RF - Right front range radar	V	V			V																												
C-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
C-CLASS	204		Information	NBR-LF - Left front range radar	V	V			V																												
C-CLASS	204		Information	NAV - Navigation module	V	V	V	V	V																												
C-CLASS	204		Information	MIF/UCI - Media interface	V	V	V		V																												
C-CLASS	204		Information	ICI - InCar Internet	V	V	V		V																												
C-CLASS	204		Information	IC - Instrument cluster	V	V	V	V	V																												
C-CLASS	204		Information	DVD player	V	V	V	V	V																												
C-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
C-CLASS	204		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
C-CLASS	204		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
C-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
C-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone	V	V			V																												
C-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
C-CLASS	204		Information	AUDIO/COMAND	V	V	V	V	V																												
C-CLASS	204		Information	AMG Performance Media	V	V	V		V																												
C-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
C-CLASS	204		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
C-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
C-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
C-CLASS	204		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
C-CLASS	204		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
C-CLASS	204		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
C-CLASS	204		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
C-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
C-CLASS	204		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
C-CLASS	205		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
C-CLASS	205		Drive	SG-EM - Power electronics	V	V			V																												
C-CLASS	205		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
C-CLASS	205		Drive	HFPM - Haptic accelerator pedal module	V	V			V																												
C-CLASS	205		Drive	DTR - Distronic	V	V	V		V																												
C-CLASS	205		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
C-CLASS	205		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V			V				V					V															V
C-CLASS	205		Drive	ETC - Electronic transmission control	V	V	V		V											V																	
C-CLASS	205		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
C-CLASS	205		Chassis	TPM - Tire pressure monitor	V	V			V																												
C-CLASS	205		Chassis	Suspension	V	V			V																												
C-CLASS	205		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V						V																						
C-CLASS	205		Chassis	ES - Electrical power steering	V	V	V		V																												
C-CLASS	205		Chassis	EFB - Electric parking brake	V	V	V	V	V																												
C-CLASS	205		Information	TPAD - Touchpad	V	V	V	V	V																												
C-CLASS	205		Information	DAB/SDAR - Digital/Satellite radio	V	V			V																												
C-CLASS	205		Information	360' - Camera	V	V	V	V	V																												
C-CLASS	205		Information	Sound generator for exhaust system	V	V			V																												
C-CLASS	205		Information	SOUND - Sound system	V	V			V																												
C-CLASS	205		Information	RFK - Backup camera	V	V	V	V	V																												
C-CLASS	205		Information	SGR - Radar sensors control unit	V	V	V		V																												
C-CLASS	205		Information	PTS - Parktronic system	V	V	V	V	V																												
C-CLASS	205		Information	NBR-RF - Right front range radar					V																												
C-CLASS	205		Information	NBR-LF - Left front range radar					V																												
C-CLASS	205		Information	MFK - Multifunction camera	V	V	V	V	V																												
C-CLASS	205		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
C-CLASS	205		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
C-CLASS	205		Information	Head-up display	V	V		V	V																												
C-CLASS	205		Information	AUDIO/COMAND	V	V			V																												
C-CLASS	205		Information	ZAN - Audio/COMAND display	V	V			V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
C-CLASS	205		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
C-CLASS	205		Information	KAB - Camera cover	V	V	V	V	V																												
C-CLASS	205		Information	IC - Instrument cluster	V	V	V	V	V																												
C-CLASS	205		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
C-CLASS	205		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
C-CLASS	205		Body	AHE - Trailer recognition	V	V			V																												
C-CLASS	205		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
C-CLASS	205		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
C-CLASS	205		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
C-CLASS	205		Body	AB - Airbag	V	V			V																												
C-CLASS	205		Body	Multifunction control unit	V	V			V																												
C-CLASS	205		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
C-CLASS	205		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
C-CLASS	205		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V														V														
C-CLASS	205		Body	SG-AWF - Collision prevention assist	V	V			V																												
C-CLASS	205		Body	EZS/EIS - Electronic ignition lock	V	V			V																												
C-CLASS	205		Body	BNS/BMS - Battery sensor	V	V	V		V																												
C-CLASS	205		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
C-CLASS	205		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
C-CLASS	205		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
C-CLASS	205		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
C-CLASS	205		Seat/Door	PSD/MSC - Sliding roof control	V	V			V																												
C-CLASS	205		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
C-CLASS	205		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
C-CLASS	205		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
C-CLASS	205		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
C-CLASS	205		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
C-CLASS	205		Seat/Door	RVC/VDS - Convertible roof control	V	V			V																												
C-CLASS	205		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
E-CLASS	124		Drive	PMS/HFM/LH	V		V		V																												
E-CLASS	124		Drive	ETC - Electronic transmission control	V		V	V	V																												
E-CLASS	124		Drive	ISC - Idle speed control	V				V																												
E-CLASS	124		Chassis	ABS/ESP - Electronic stability program	V		V		V																												
E-CLASS	124		Body	AB - Airbag	V		V		V																												
E-CLASS	210		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V							V						V											
E-CLASS	210		Drive	ETC - Electronic transmission control	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
E-CLASS	210		Drive	ESM - Electronic selector module	V	V	V	V	V																												
E-CLASS	210		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
E-CLASS	210		Chassis	VP - Vacuum pump brake booster	V	V	V	V	V																												
E-CLASS	210		Chassis	PSE - Pneumatic system equipment	V				V																												
E-CLASS	210		Chassis	BAS - Brake assist	V	V	V		V																												
E-CLASS	210		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V				V																												
E-CLASS	210		Body	OCP - Overhead control panel	V		V		V																												
E-CLASS	210		Body	LCP/HBF - Lower/Rear control panel	V		V	V	V																												
E-CLASS	210		Body	EZS/EIS - Electronic ignition lock	V		V		V																												
E-CLASS	210		Body	AB - Airbag	V	V	V		V																												
E-CLASS	210		Information	TV - TV tuner	V	V		V	V																												
E-CLASS	210		Information	PTS - Parktronic system	V	V	V	V	V																												
E-CLASS	210		Information	NAV - Navigation module	V	V			V																												
E-CLASS	210		Information	IC - Instrument cluster	V	V	V	V	V																		V										
E-CLASS	210		Information	DTA - Mbrace or TELEAID/GPS Box	V	V		V	V												V																
E-CLASS	210		Information	AUDIO/COMAND	V	V		V	V																												
E-CLASS	210		Information	APS - Auto pilot system	V	V			V																												
E-CLASS	210		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V				V																												
E-CLASS	210		Seat/Door	ESA Driver - Electric seat adjustment Driver	V				V																												
E-CLASS	210		Seat/Door	DCM-RR - Door control module rear right	V				V																												
E-CLASS	210		Seat/Door	DCM-RL - Door control module rear left	V				V																												
E-CLASS	210		Seat/Door	DCM-FR - Door control module front right	V				V																												
E-CLASS	210		Seat/Door	DCM-FL - Door control module front left	V				V																												
E-CLASS	210		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
E-CLASS	210		Air Conditioning	HB - Heater booster	V	V	V	V	V																												
E-CLASS	210		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
E-CLASS	211		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V							V			V		V				V								
E-CLASS	211		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
E-CLASS	211		Drive	ESM - Electronic selector module	V	V	V	V	V																												
E-CLASS	211		Drive	Natural gas control unit	V	V			V																												
E-CLASS	211		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V		V																								V				
E-CLASS	211		Drive	DTR - Distronic	V	V	V		V																												
E-CLASS	211		Drive	Compressed Natural Gas Control Module	V	V			V																												
E-CLASS	211		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
E-CLASS	211		Chassis	Suspension	V	V	V	V	V																												
E-CLASS	211		Chassis	SBC - Sensotronic Brake Control	V	V	V		V								V																				

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
E-CLASS	211		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
E-CLASS	211		Body	WSS - Weight sensing system	V	V	V		V																												
E-CLASS	211		Body	UCP - Upper control panel	V	V	V	V	V																												
E-CLASS	211		Body	System diagnosis	V	V			V																												
E-CLASS	211		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
E-CLASS	211		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
E-CLASS	211		Body	SAM-P- Passenger-side signal acquisition and actuation module	V	V	V	V	V																												
E-CLASS	211		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V																												
E-CLASS	211		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V	V	V																												
E-CLASS	211		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V	V	V																												
E-CLASS	211		Body	OCP - Overhead control panel	V	V	V	V	V																												
E-CLASS	211		Body	Multifunction control unit	V	V	V	V	V																												
E-CLASS	211		Body	LCP/HBF - Lower/Rear control panel	V	V	V	V	V																												
E-CLASS	211		Body	LAE [LAA] - Loading floor automatically extendable	V	V	V	V	V																												
E-CLASS	211		Body	HSW/LRH - Steering wheel heater	V	V	V	V	V																												
E-CLASS	211		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
E-CLASS	211		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
E-CLASS	211		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
E-CLASS	211		Body	CGW - Central gateway	V	V			V																												
E-CLASS	211		Body	BNS/BMS - Battery sensor	V	V	V	V	V																												
E-CLASS	211		Body	AHE - Trailer recognition	V	V	V	V	V																												
E-CLASS	211		Body	AB - Airbag	V	V	V		V																												
E-CLASS	211		Information	TV - TV tuner	V	V			V																												
E-CLASS	211		Information	SOUND - Sound system	V	V	V	V	V																												
E-CLASS	211		Information	PTS - Parktronic system	V	V	V	V	V																												
E-CLASS	211		Information	MIF/UCI - Media interface	V	V	V		V																												
E-CLASS	211		Information	IC - Instrument cluster	V	V	V	V	V																												
E-CLASS	211		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
E-CLASS	211		Information	DAB/SDAR - Digital/Satellite radio	V	V	V		V																												
E-CLASS	211		Information	CTEL/TEL - Cellular/Mobile telephone	V	V	V		V																												
E-CLASS	211		Information	AUDIO/COMAND	V	V	V	V	V																												
E-CLASS	211		Information	ASSYST PLUS - PLUS Active Service System	V	V	V		V																												
E-CLASS	211		Information	ASSYST Active Service System	V	V	V		V																										V		
E-CLASS	211		Information	AGW - Audio gateway	V	V	V	V	V																												
E-CLASS	211		Seat/Door	REDC/RWT - Rear end door control module	V	V	V	V	V																												
E-CLASS	211		Seat/Door	HS - Seat heater	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
E-CLASS	211		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
E-CLASS	211		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
E-CLASS	211		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																				V								
E-CLASS	211		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V	V	V																												
E-CLASS	211		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																				V								
E-CLASS	211		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
E-CLASS	211		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
E-CLASS	211		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
E-CLASS	211		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
E-CLASS	211		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
E-CLASS	211		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
E-CLASS	207		Drive	SG-EM - Power electronics	V	V			V																												
E-CLASS	207		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
E-CLASS	207		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V					V						V							V						V
E-CLASS	207		Drive	ETC - Electronic transmission control	V	V	V	V	V												V																
E-CLASS	207		Drive	ESM - Electronic selector module	V	V	V	V	V																												
E-CLASS	207		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
E-CLASS	207		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
E-CLASS	207		Drive	DTR - Distronic	V	V	V		V																												
E-CLASS	207		Drive	DSI - Direct select interface	V	V	V	V	V																												
E-CLASS	207		Drive	AMG DRIVE UNIT	V	V	V	V	V																												
E-CLASS	207		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
E-CLASS	207		Chassis	Suspension	V	V	V	V	V																												
E-CLASS	207		Chassis	ES - Electrical power steering	V	V	V		V																												
E-CLASS	207		Chassis	FWGW - Chassis gateway	V	V	V		V																												
E-CLASS	207		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
E-CLASS	207		Body	BNS/BMS - Battery sensor	V	V	V		V																												
E-CLASS	207		Body	WSS - Weight sensing system	V	V	V		V																												
E-CLASS	207		Body	SG-AWF - Collision prevention assist	V	V	V		V																												
E-CLASS	207		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
E-CLASS	207		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
E-CLASS	207		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
E-CLASS	207		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
E-CLASS	207		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
E-CLASS	207		Body	Multifunction control unit	V	V	V	V	V																												
E-CLASS	207		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
E-CLASS	207		Body	HS/AIRSCARF - Seat heater/Air scarf system	V	V	V	V	V																												
E-CLASS	207		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
E-CLASS	207		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
E-CLASS	207		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
E-CLASS	207		Body	CGW - Central gateway	V	V	V		V																												
E-CLASS	207		Body	AHE - Trailer recognition	V	V	V	V	V																												
E-CLASS	207		Body	AB - Airbag	V	V	V		V																												
E-CLASS	207		Information	NBR-RF - Right front range radar	V	V			V																												
E-CLASS	207		Information	NBR-LF - Left front range radar	V	V			V																												
E-CLASS	207		Information	AVE-H - Rear audio video unit	V	V			V																												
E-CLASS	207		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
E-CLASS	207		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
E-CLASS	207		Information	TV - TV tuner	V	V	V		V																												
E-CLASS	207		Information	SOUND - Sound system	V	V	V	V	V																												
E-CLASS	207		Information	SGR - Radar sensors control unit	V	V	V		V																												
E-CLASS	207		Information	360' - Camera	V	V	V		V																												
E-CLASS	207		Information	MFK - Multifunction camera	V	V	V	V	V																												
E-CLASS	207		Information	RFK - Backup camera	V	V	V	V	V																												
E-CLASS	207		Information	PTS - Parktronic system	V	V	V	V	V																												
E-CLASS	207		Information	NSA - Night View Assist	V	V	V		V																												
E-CLASS	207		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
E-CLASS	207		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
E-CLASS	207		Information	NAV - Navigation module	V	V	V	V	V																												
E-CLASS	207		Information	MIF/UCI - Media interface	V	V	V		V																												
E-CLASS	207		Information	ICI - InCar Internet	V	V	V		V																												
E-CLASS	207		Information	IC - Instrument cluster	V	V	V	V	V																												
E-CLASS	207		Information	DVD player	V	V	V	V	V																												
E-CLASS	207		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
E-CLASS	207		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
E-CLASS	207		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
E-CLASS	207		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
E-CLASS	207		Information	CTEL/TEL - Cellular/Mobile telephone	V	V			V																												
E-CLASS	207		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
E-CLASS	207		Information	AUDIO/COMAND	V	V	V	V	V																												
E-CLASS	207		Seat/Door	RVC/VDS - Convertible roof control	V	V	V	V	V																												
E-CLASS	207		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
E-CLASS	207		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
E-CLASS	207		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
E-CLASS	207		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
E-CLASS	207		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
E-CLASS	207		Air Conditioning	EKMK - Electric refrigerant compressor	V	V			V																												
E-CLASS	207		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
E-CLASS	207		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
E-CLASS	212		Drive	SG-EM - Power electronics	V	V			V																												
E-CLASS	212		Drive	Compressed Natural Gas Control Module	V	V			V																												
E-CLASS	212		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V					V						V						V							V
E-CLASS	212		Drive	ETC - Electronic transmission control	V	V	V	V	V												V																
E-CLASS	212		Drive	ESM - Electronic selector module	V	V	V	V	V																												
E-CLASS	212		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
E-CLASS	212		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
E-CLASS	212		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
E-CLASS	212		Drive	DTR - Distronic	V	V	V		V																												
E-CLASS	212		Drive	DSI - Direct select interface	V	V	V	V	V																												
E-CLASS	212		Drive	AMG DRIVE UNIT	V	V	V	V	V																												
E-CLASS	212		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
E-CLASS	212		Chassis	Suspension	V	V	V	V	V																												
E-CLASS	212		Chassis	ES - Electrical power steering	V	V	V		V																												
E-CLASS	212		Chassis	FWGW - Chassis gateway	V	V	V		V																												
E-CLASS	212		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
E-CLASS	212		Body	BNS/BMS - Battery sensor	V	V	V		V																												
E-CLASS	212		Body	WSS - Weight sensing system	V	V	V		V																												
E-CLASS	212		Body	SG-AWF - Collision prevention assist	V	V	V		V																												
E-CLASS	212		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
E-CLASS	212		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
E-CLASS	212		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
E-CLASS	212		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
E-CLASS	212		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
E-CLASS	212		Body	OCP - Overhead control panel	V	V	V	V	V																												
E-CLASS	212		Body	Multifunction control unit	V	V	V	V	V																												
E-CLASS	212		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
E-CLASS	212		Body	HSW/LRH - Steering wheel heater	V	V	V		V																												
E-CLASS	212		Body	HS/AIRSCARF - Seat heater/Air scarf system	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
E-CLASS	212		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
E-CLASS	212		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
E-CLASS	212		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
E-CLASS	212		Body	CGW - Central gateway	V	V	V		V																												
E-CLASS	212		Body	AHE - Trailer recognition	V	V	V	V	V																												
E-CLASS	212		Body	AB - Airbag	V	V	V		V																												
E-CLASS	212		Information	Head-up display	V	V			V																												
E-CLASS	212		Information	AVE-H - Rear audio video unit	V	V			V																												
E-CLASS	212		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
E-CLASS	212		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
E-CLASS	212		Information	TV - TV tuner	V	V	V		V																												
E-CLASS	212		Information	SOUND - Sound system	V	V	V	V	V																												
E-CLASS	212		Information	SGR - Radar sensors control unit	V	V	V		V																												
E-CLASS	212		Information	360' - Camera	V	V	V		V																												
E-CLASS	212		Information	MFK - Multifunction camera	V	V	V	V	V																												
E-CLASS	212		Information	RFK - Backup camera	V	V	V	V	V																												
E-CLASS	212		Information	PTS - Parktronic system	V	V	V	V	V																												
E-CLASS	212		Information	NSA - Night View Assist	V	V	V	V	V																												
E-CLASS	212		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
E-CLASS	212		Information	NBR-RF - Right front range radar	V	V			V																												
E-CLASS	212		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
E-CLASS	212		Information	NBR-LF - Left front range radar	V	V			V																												
E-CLASS	212		Information	NAV - Navigation module	V	V	V	V	V																												
E-CLASS	212		Information	MIF/UCI - Media interface	V	V	V		V																												
E-CLASS	212		Information	ICI - InCar Internet	V	V	V		V																												
E-CLASS	212		Information	IC - Instrument cluster	V	V	V	V	V																												
E-CLASS	212		Information	DVD player	V	V	V	V	V																												
E-CLASS	212		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
E-CLASS	212		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
E-CLASS	212		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
E-CLASS	212		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
E-CLASS	212		Information	CTEL/TEL - Cellular/Mobile telephone	V	V			V																												
E-CLASS	212		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
E-CLASS	212		Information	AUDIO/COMAND	V	V	V	V	V																												
E-CLASS	212		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
E-CLASS	212		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
E-CLASS	212		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
E-CLASS	212		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
E-CLASS	212		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																												
E-CLASS	212		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V		V																												
E-CLASS	212		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																												
E-CLASS	212		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
E-CLASS	212		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
E-CLASS	212		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
E-CLASS	212		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
E-CLASS	212		Air Conditioning	EKMK - Electric refrigerant compressor	V	V			V																												
E-CLASS	212		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
E-CLASS	212		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
E-CLASS	213		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
E-CLASS	213		Drive	DTR - Distronic	V	V			V																												
E-CLASS	213		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
E-CLASS	213		Drive	HFPM - Haptic accelerator pedal module	V	V			V																												
E-CLASS	213		Drive	AMG DRIVE UNIT	V	V	V	V	V																												
E-CLASS	213		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
E-CLASS	213		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
E-CLASS	213		Drive	ETC - Electronic transmission control	V	V	V		V												V																
E-CLASS	213		Chassis	TPM - Tire pressure monitor	V	V			V																												
E-CLASS	213		Chassis	AIRMATIC PLUS	V	V			V																												
E-CLASS	213		Chassis	ES - Electrical power steering	V	V	V		V																												
E-CLASS	213		Chassis	Suspension	V	V			V																												
E-CLASS	213		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V							V																					
E-CLASS	213		Body	MTAS - Mobile phone cradle	V	V			V																												
E-CLASS	213		Body	AHE - Trailer recognition	V	V			V																												
E-CLASS	213		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
E-CLASS	213		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
E-CLASS	213		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
E-CLASS	213		Body	SG-LML-VR - LED matrix of right front lamp unit	V	V			V																												
E-CLASS	213		Body	SG-LML-VL - LED matrix of left front lamp unit	V	V			V																												
E-CLASS	213		Body	AB - Airbag	V	V			V																												
E-CLASS	213		Body	OCP - Overhead control panel	V	V			V																												
E-CLASS	213		Body	Multifunction control unit	V	V			V																												
E-CLASS	213		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
E-CLASS	213		Body	SG-DDW - DC/DC converter control unit	V	V			V																												
E-CLASS	213		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
E-CLASS	213		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V														V														
E-CLASS	213		Body	SG-AWF - Collision prevention assist	V	V			V																												
E-CLASS	213		Body	EZS/EIS - Electronic ignition lock	V	V			V																												
E-CLASS	213		Body	BNS/BMS - Battery sensor	V	V	V		V																												
E-CLASS	213		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
E-CLASS	213		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
E-CLASS	213		Body	AML - Ambiance light	V	V			V																												
E-CLASS	213		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
E-CLASS	213		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
E-CLASS	213		Seat/Door	Right rear ESE - Right electrical seat adjustment	V	V			V																												
E-CLASS	213		Seat/Door	Left rear ESE - Left electrical seat adjustment	V	V			V																												
E-CLASS	213		Seat/Door	PSD/MSC - Sliding roof control	V	V			V																												
E-CLASS	213		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
E-CLASS	213		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V			V																												
E-CLASS	213		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat	V	V			V																												
E-CLASS	213		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat	V	V			V																												
E-CLASS	213		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V			V																												
E-CLASS	213		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V			V																												
E-CLASS	213		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
E-CLASS	213		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
E-CLASS	213		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
E-CLASS	213		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
E-CLASS	213		Seat/Door	RVC/VDS - Convertible roof control	V	V			V																												
E-CLASS	213		Information	DAB/SDAR - Digital/Satellite radio	V	V			V																												
E-CLASS	213		Information	TPAD - Touchpad	V	V	V	V	V																												
E-CLASS	213		Information	Sound generator for exhaust system	V	V			V																												
E-CLASS	213		Information	SOUND - Sound system	V	V			V																												
E-CLASS	213		Information	RFK - Backup camera	V	V	V	V	V																												
E-CLASS	213		Information	PTS - Parktronic system	V	V	V	V	V																												
E-CLASS	213		Information	MFK - Multifunction camera	V	V	V	V	V																												
E-CLASS	213		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
E-CLASS	213		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
E-CLASS	213		Information	SGR - Radar sensors control unit	V	V	V		V																												
E-CLASS	213		Information	IC - Instrument cluster	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
E-CLASS	213		Information	Head-up display	V	V		V	V																												
E-CLASS	213		Information	AUDIO/COMAND	V	V			V																												
E-CLASS	213		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
E-CLASS	213		Information	ZAN - Audio/COMAND display	V	V			V																												
E-CLASS	213		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
E-CLASS	213		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
S-CLASS	140		Drive	ASF	V		V		V																												
S-CLASS	140		Drive	ERE	V		V		V																												
S-CLASS	140		Drive	ME1LI	V		V	V	V																												
S-CLASS	140		Drive	ME1RE	V		V	V	V																												
S-CLASS	140		Drive	HFM/ME2/LH	V		V	V	V																												
S-CLASS	140		Drive	ETC - Electronic transmission control	V		V	V	V																												
S-CLASS	140		Drive	ISC - Idle speed control	V				V																												
S-CLASS	140		Chassis	ABS/ESP - Electronic stability program	V		V		V																												
S-CLASS	140		Chassis	BAS - Brake assist	V		V		V																												
S-CLASS	140		Body	PSE - Pneumatic system equipment	V				V																												
S-CLASS	140		Body	AB - Airbag	V		V		V																												
S-CLASS	140		Information	PTS - Parktronic system	V		V		V																												
S-CLASS	140		Information	IC - Instrument cluster	V		V	V	V																												
S-CLASS	140		Air Conditioning	AAC - Automatic air conditioning	V		V		V																												
S-CLASS	220		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V							V			V		V					V							
S-CLASS	220		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
S-CLASS	220		Drive	ESM - Electronic selector module	V	V	V	V	V																												
S-CLASS	220		Drive	DTR - Distronic	V	V	V		V																												
S-CLASS	220		Chassis	TPM - Tire pressure monitor	V	V			V																												
S-CLASS	220		Chassis	Suspension	V	V	V	V	V																												
S-CLASS	220		Chassis	PSE - Pneumatic system equipment	V	V		V	V																												
S-CLASS	220		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
S-CLASS	220		Body	UCP - Upper control panel	V	V	V	V	V																												
S-CLASS	220		Body	System diagnosis	V	V			V																												
S-CLASS	220		Body	SCM [MRM] - Steering column module	V	V		V	V																												
S-CLASS	220		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V		V	V																												
S-CLASS	220		Body	SAM-P- Passenger-side signal acquisition and actuation module	V	V		V	V																												
S-CLASS	220		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V		V	V																												
S-CLASS	220		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V	V	V																												
S-CLASS	220		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
S-CLASS	220		Body	OCP - Overhead control panel	V	V	V	V	V																												
S-CLASS	220		Body	Multifunction control unit	V	V		V	V																												
S-CLASS	220		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V	V	V																												
S-CLASS	220		Body	HSW/LRH - Steering wheel heater	V	V		V	V																												
S-CLASS	220		Body	Headlamp-R - Headlamp control unit	V	V	V		V																												
S-CLASS	220		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
S-CLASS	220		Body	EZS/EIS - Electronic ignition lock	V	V			V																												
S-CLASS	220		Body	CGW - Central gateway	V	V			V																												
S-CLASS	220		Body	AHE - Trailer recognition	V	V		V	V																												
S-CLASS	220		Body	AB - Airbag	V	V	V		V																												
S-CLASS	220		Information	TV - TV tuner	V	V		V	V																												
S-CLASS	220		Information	PTS - Parktronic system	V	V	V	V	V																												
S-CLASS	220		Information	NAV - Navigation module	V	V			V																												
S-CLASS	220		Information	IC - Instrument cluster	V	V	V	V	V																		V										
S-CLASS	220		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V	V	V													V															
S-CLASS	220		Information	AUDIO/COMAND	V	V		V	V																												
S-CLASS	220		Information	AGW - Audio gateway	V	V		V	V																												
S-CLASS	220		Seat/Door	OSB-R - Multicontour backrest rear	V	V		V	V																												
S-CLASS	220		Seat/Door	OSB-FL - Multicontour backrest front left	V	V		V	V																												
S-CLASS	220		Seat/Door	ESA-R - Electric seat adjustment rear	V	V		V	V																												
S-CLASS	220		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V		V	V																												
S-CLASS	220		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V		V	V																												
S-CLASS	220		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																												
S-CLASS	220		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V	V	V																												
S-CLASS	220		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																												
S-CLASS	220		Seat/Door	DCM-RR - Door control module rear right	V	V		V	V																												
S-CLASS	220		Seat/Door	DCM-RL - Door control module rear left	V	V		V	V																												
S-CLASS	220		Seat/Door	DCM-FR - Door control module front right	V	V		V	V																												
S-CLASS	220		Seat/Door	DCM-FL - Door control module front left	V	V		V	V																												
S-CLASS	220		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
S-CLASS	220		Air Conditioning	KBE-H/REAR AC - Rear air conditioning	V	V		V	V																												
S-CLASS	220		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
S-CLASS	221		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V					V						V							V						V
S-CLASS	221		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
S-CLASS	221		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
S-CLASS	221		Drive	ISM - Intelligent servo module	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
S-CLASS	221		Drive	HSG - Hybrid control unit	V	V	V	V	V							V																					
S-CLASS	221		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
S-CLASS	221		Drive	DTR - Distronic	V	V	V		V																												
S-CLASS	221		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
S-CLASS	221		Chassis	Suspension	V	V	V	V	V																												
S-CLASS	221		Chassis	ES - Electrical power steering	V	V	V		V																												
S-CLASS	221		Chassis	EFB - Electric parking brake	V	V	V	V	V																												
S-CLASS	221		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
S-CLASS	221		Body	WSS - Weight sensing system	V	V	V		V																												
S-CLASS	221		Body	UCP - Upper control panel	V	V	V	V	V																												
S-CLASS	221		Body	System diagnosis	V	V			V																												
S-CLASS	221		Body	SG-DDW - DC/DC converter control unit	V	V	V		V																												
S-CLASS	221		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
S-CLASS	221		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V		V																												
S-CLASS	221		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V																												
S-CLASS	221		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
S-CLASS	221		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
S-CLASS	221		Body	OCP - Overhead control panel	V	V	V	V	V																												
S-CLASS	221		Body	Multifunction control unit	V	V	V	V	V																												
S-CLASS	221		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
S-CLASS	221		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
S-CLASS	221		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
S-CLASS	221		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
S-CLASS	221		Body	CGW - Central gateway	V	V			V																												
S-CLASS	221		Body	BNS/BMS - Battery sensor	V	V	V	V	V																												
S-CLASS	221		Body	AHE - Trailer recognition	V	V	V	V	V																												
S-CLASS	221		Body	AB - Airbag	V	V	V		V																												
S-CLASS	221		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
S-CLASS	221		Information	VCS - Voice control	V	V	V		V																												
S-CLASS	221		Information	TV - TV tuner	V	V	V		V																												
S-CLASS	221		Information	Tuner - Standard tuner	V	V	V		V																												
S-CLASS	221		Information	SOUND - Sound system	V	V	V	V	V																												
S-CLASS	221		Information	SGR - Radar sensors control unit	V	V	V	V	V																												
S-CLASS	221		Information	MFK - Multifunction camera	V	V	V	V	V																												
S-CLASS	221		Information	RFK - Backup camera	V	V	V		V																												
S-CLASS	221		Information	PTS - Parktronic system	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
S-CLASS	221		Information	NSA - Night View Assist	V	V	V	V	V																												
S-CLASS	221		Information	NBR-LF - Left front range radar	V	V			V																												
S-CLASS	221		Information	NAV - Navigation module	V	V	V	V	V																												
S-CLASS	221		Information	MIF/UCI - Media interface	V	V	V		V																												
S-CLASS	221		Information	ICI - InCar Internet	V	V	V		V																												
S-CLASS	221		Information	IC - Instrument cluster	V	V	V	V	V																												
S-CLASS	221		Information	DVD player	V	V	V	V	V																												
S-CLASS	221		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
S-CLASS	221		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
S-CLASS	221		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
S-CLASS	221		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
S-CLASS	221		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
S-CLASS	221		Information	AVE-H - Rear audio video unit	V	V	V	V	V																												
S-CLASS	221		Information	AUDIO/COMAND	V	V	V	V	V																												
S-CLASS	221		Information	ASSYST PLUS - PLUS Active Service System	V	V	V		V																												
S-CLASS	221		Information	ASSYST Active Service System	V	V	V		V																										V		
S-CLASS	221		Seat/Door	TSG-MR - Right center door control unit	V	V	V		V																												
S-CLASS	221		Seat/Door	TSG-ML - Left center door control unit	V	V	V		V																												
S-CLASS	221		Seat/Door	TLC/GTO - Garage door opener	V	V	V		V																												
S-CLASS	221		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
S-CLASS	221		Seat/Door	MKL-HR - Rear right multicontour backrest	V	V	V		V																												
S-CLASS	221		Seat/Door	MKL-HL - Rear left multicontour backrest	V	V	V		V																												
S-CLASS	221		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
S-CLASS	221		Seat/Door	ESA-R - Electric seat adjustment rear	V	V	V	V	V																												
S-CLASS	221		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
S-CLASS	221		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
S-CLASS	221		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																												
S-CLASS	221		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V		V																												
S-CLASS	221		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																												
S-CLASS	221		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
S-CLASS	221		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
S-CLASS	221		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
S-CLASS	221		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
S-CLASS	221		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
S-CLASS	221		Air Conditioning	KBE-H/REAR AC - Rear air conditioning	V	V	V	V	V																												
S-CLASS	221		Air Conditioning	HBF - Rear control panel	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
S-CLASS	221		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
S-CLASS	217		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
S-CLASS	217		Drive	SG-EM - Power electronics	V	V			V																												
S-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
S-CLASS	217		Drive	DTR - Distronic	V	V			V																												
S-CLASS	217		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
S-CLASS	217		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
S-CLASS	217		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
S-CLASS	217		Drive	ETC - Electronic transmission control	V	V	V		V												V																
S-CLASS	217		Chassis	TPM - Tire pressure monitor	V	V			V																												
S-CLASS	217		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V							V																					
S-CLASS	217		Chassis	ES - Electrical power steering	V	V	V		V																												
S-CLASS	217		Chassis	Suspension	V	V			V																												
S-CLASS	217		Chassis	EFB - Electric parking brake	V	V	V	V	V																												
S-CLASS	217		Information	TPAD - Touchpad	V	V	V	V	V																												
S-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio	V	V			V																												
S-CLASS	217		Information	360' - Camera	V	V	V	V	V																												
S-CLASS	217		Information	SOUND - Sound system	V	V			V																												
S-CLASS	217		Information	RFK - Backup camera	V	V	V	V	V																												
S-CLASS	217		Information	SGR - Radar sensors control unit	V	V	V		V																												
S-CLASS	217		Information	PTS - Parktronic system	V	V	V	V	V																												
S-CLASS	217		Information	NSA - Night View Assist	V	V			V																												
S-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
S-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
S-CLASS	217		Information	NBR-RF - Right front range radar					V																												
S-CLASS	217		Information	NBR-LF - Left front range radar					V																												
S-CLASS	217		Information	MFK - Multifunction camera	V	V	V	V	V																												
S-CLASS	217		Information	Head-up display	V	V		V	V																												
S-CLASS	217		Information	AUDIO/COMAND	V	V			V																												
S-CLASS	217		Information	ZAN - Audio/COMAND display	V	V			V																												
S-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
S-CLASS	217		Information	KAB - Camera cover	V	V	V	V	V																												
S-CLASS	217		Information	IC - Instrument cluster	V	V	V	V	V																												
S-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
S-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
S-CLASS	217		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
S-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
S-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
S-CLASS	217		Body	AB - Airbag	V	V			V																												
S-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
S-CLASS	217		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
S-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V														V														
S-CLASS	217		Body	SG-AWF - Collision prevention assist	V	V			V																												
S-CLASS	217		Body	EZS/EIS - Electronic ignition lock	V	V			V																												
S-CLASS	217		Body	BNS/BMS - Battery sensor	V	V	V		V																												
S-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
S-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
S-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
S-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
S-CLASS	217		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
S-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V			V																												
S-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V			V																												
S-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V			V																												
S-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control	V	V			V																												
S-CLASS	217		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
S-CLASS	217		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
S-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control	V	V			V																												
S-CLASS	217		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
S-CLASS	222		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
S-CLASS	222		Drive	SG-EM - Power electronics	V	V			V																												
S-CLASS	222		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
S-CLASS	222		Drive	DTR - Distronic	V	V			V																												
S-CLASS	222		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
S-CLASS	222		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
S-CLASS	222		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
S-CLASS	222		Drive	ETC - Electronic transmission control	V	V	V		V												V																
S-CLASS	222		Chassis	TPM - Tire pressure monitor	V	V			V																												
S-CLASS	222		Chassis	ES - Electrical power steering	V	V	V		V																												
S-CLASS	222		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V							V																					
S-CLASS	222		Chassis	Suspension	V	V			V																												
S-CLASS	222		Chassis	EFB - Electric parking brake	V	V	V	V	V																												
S-CLASS	222		Information	TPAD - Touchpad	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
S-CLASS	222		Information	DAB/SDAR - Digital/Satellite radio	V	V			V																												
S-CLASS	222		Information	360' - Camera	V	V	V	V	V																												
S-CLASS	222		Information	Sound generator for exhaust system	V	V			V																												
S-CLASS	222		Information	SOUND - Sound system	V	V			V																												
S-CLASS	222		Information	RFK - Backup camera	V	V	V	V	V																												
S-CLASS	222		Information	SGR - Radar sensors control unit	V	V	V		V																												
S-CLASS	222		Information	PTS - Parktronic system	V	V	V	V	V																												
S-CLASS	222		Information	NSA - Night View Assist	V	V			V																												
S-CLASS	222		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
S-CLASS	222		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
S-CLASS	222		Information	NBR-RF - Right front range radar					V																												
S-CLASS	222		Information	NBR-LF - Left front range radar					V																												
S-CLASS	222		Information	MFK - Multifunction camera	V	V	V	V	V																												
S-CLASS	222		Information	Head-up display	V	V		V	V																												
S-CLASS	222		Information	AUDIO/COMAND	V	V			V																												
S-CLASS	222		Information	AVE-H - Rear audio video unit	V	V			V																												
S-CLASS	222		Information	ZAN - Audio/COMAND display	V	V			V																												
S-CLASS	222		Information	D-FOR - Display in right rear passenger	V	V			V																												
S-CLASS	222		Information	D-FOL - Display in left rear passenger	V	V			V																												
S-CLASS	222		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
S-CLASS	222		Information	KAB - Camera cover	V	V	V	V	V																												
S-CLASS	222		Information	IC - Instrument cluster	V	V	V	V	V																												
S-CLASS	222		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
S-CLASS	222		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
S-CLASS	222		Body	AHE - Trailer recognition	V	V			V																												
S-CLASS	222		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
S-CLASS	222		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
S-CLASS	222		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
S-CLASS	222		Body	AB - Airbag	V	V			V																												
S-CLASS	222		Body	Multifunction control unit	V	V			V																												
S-CLASS	222		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
S-CLASS	222		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
S-CLASS	222		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V														V														
S-CLASS	222		Body	FLANFS - Fire extinguishing system and emergency fresh air system	V	V			V																												
S-CLASS	222		Body	SG-AWF - Collision prevention assist	V	V			V																												
S-CLASS	222		Body	EZS/EIS - Electronic ignition lock	V	V			V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
S-CLASS	222		Body	BNS/BMS - Battery sensor	V	V	V		V																												
S-CLASS	222		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
S-CLASS	222		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
S-CLASS	222		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
S-CLASS	222		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
S-CLASS	222		Seat/Door	Right rear ESE - Right electrical seat adjustment	V	V			V																												
S-CLASS	222		Seat/Door	Left rear ESE - Left electrical seat adjustment	V	V			V																												
S-CLASS	222		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
S-CLASS	222		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V			V																												
S-CLASS	222		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat	V	V			V																												
S-CLASS	222		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat	V	V			V																												
S-CLASS	222		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V			V																												
S-CLASS	222		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V			V																												
S-CLASS	222		Seat/Door	PSD/MSC - Sliding roof control	V	V			V																												
S-CLASS	222		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
S-CLASS	222		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
S-CLASS	222		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
S-CLASS	222		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
S-CLASS	222		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V			V																												
S-CLASS	222		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
G-CLASS	461 - 38P Connector		Drive	EVE	V		V		V																												
G-CLASS	461 - 38P Connector		Chassis	ABS/ESP - Electronic stability program	V		V		V																												
G-CLASS	461 - 38P Connector		Body	AB - Airbag	V		V		V																												
G-CLASS	461 - 38P Connector		Information	IC - Instrument cluster	V		V	V	V																												
G-CLASS	461 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control	V				V																												
G-CLASS	461 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V		V				V		V											V
G-CLASS	461 - 16P Connector		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
G-CLASS	461 - 16P Connector		Drive	ESM - Electronic selector module	V	V	V	V	V																												
G-CLASS	461 - 16P Connector		Drive	VG - Transfer case	V	V	V	V	V																												
G-CLASS	461 - 16P Connector		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
G-CLASS	461 - 16P Connector		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
G-CLASS	461 - 16P Connector		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
G-CLASS	461 - 16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V			V																												
G-CLASS	461 - 16P Connector		Body	CGW - Central gateway	V	V			V																												
G-CLASS	461 - 16P Connector		Body	AB - Airbag	V	V	V		V																												
G-CLASS	461 - 16P Connector		Information	IC - Instrument cluster	V	V			V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
G-CLASS	461 - 16P Connector		Information	AGW - Audio gateway	V	V	V	V	V																												
G-CLASS	461 - 16P Connector		Information	AUDIO/COMAND	V	V		V	V																												
G-CLASS	461 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
G-CLASS	463 - 38P Connector		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V																												
G-CLASS	463 - 38P Connector		Drive	ETC - Electronic transmission control	V		V	V	V																												
G-CLASS	463 - 38P Connector		Drive	ESM - Electronic selector module	V	V	V	V	V																												
G-CLASS	463 - 38P Connector		Drive	CC - Cruise control	V		V		V																												
G-CLASS	463 - 38P Connector		Chassis	ABS/ESP - Electronic stability program	V		V		V																												
G-CLASS	463 - 38P Connector		Body	AB - Airbag	V		V		V																												
G-CLASS	463 - 38P Connector		Information	IC - Instrument cluster	V	V	V	V	V																			V									
G-CLASS	463 - 38P Connector		Information	AUDIO/COMAND	V	V		V	V																												
G-CLASS	463 - 38P Connector		Information	APS - Auto pilot system	V	V			V																												
G-CLASS	463 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V					V		V				V		V					V						V
G-CLASS	463 - 16P Connector		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Drive	ESM - Electronic selector module	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Drive	VG - Transfer case	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Drive	DTR - Distronic	V	V	V		V																												
G-CLASS	463 - 16P Connector		Drive	DSI - Direct select interface	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
G-CLASS	463 - 16P Connector		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
G-CLASS	463 - 16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system	V	V			V																												
G-CLASS	463 - 16P Connector		Body	UCP - Upper control panel	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
G-CLASS	463 - 16P Connector		Body	OCP - Overhead control panel	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Body	Multifunction control unit	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Body	HSW/LRH - Steering wheel heater	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
G-CLASS	463 - 16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
G-CLASS	463 - 16P Connector		Body	AHE - Trailer recognition	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
G-CLASS	463 - 16P Connector		Body	AB - Airbag	V	V	V		V																												
G-CLASS	463 - 16P Connector		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Information	TV - TV tuner	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Information	SOUND - Sound system	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Information	PTS - Parktronic system	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
G-CLASS	463 - 16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
G-CLASS	463 - 16P Connector		Information	NAV - Navigation module	V	V			V																												
G-CLASS	463 - 16P Connector		Information	MIF/UCI - Media interface	V	V	V		V																												
G-CLASS	463 - 16P Connector		Information	IC - Instrument cluster	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V	V	V													V															
G-CLASS	463 - 16P Connector		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone	V	V	V		V																												
G-CLASS	463 - 16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Information	AUDIO/COMAND	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Information	AGW - Audio gateway	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Seat/Door	HS - Seat heater	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
G-CLASS	463 - 16P Connector		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
GLA-CLASS	156		Drive	VG - Transfer case	V	V			V																												
GLA-CLASS	156		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
GLA-CLASS	156		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
GLA-CLASS	156		Drive	ETC - Electronic transmission control	V	V	V		V												V																
GLA-CLASS	156		Drive	DTR - Distronic	V	V	V		V																												
GLA-CLASS	156		Drive	DSI - Direct select interface	V	V	V	V	V																												
GLA-CLASS	156		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
GLA-CLASS	156		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
GLA-CLASS	156		Chassis	ES - Electrical power steering	V	V	V		V																												
GLA-CLASS	156		Chassis	EFB - Electric parking brake	V	V	V		V																												
GLA-CLASS	156		Chassis	TPM - Tire pressure monitor	V	V	V		V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
GLA-CLASS	156		Body	SG-AWF - Collision prevention assist	V	V	V		V																												
GLA-CLASS	156		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
GLA-CLASS	156		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
GLA-CLASS	156		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
GLA-CLASS	156		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
GLA-CLASS	156		Body	Multifunction control unit	V	V	V	V	V																												
GLA-CLASS	156		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
GLA-CLASS	156		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
GLA-CLASS	156		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
GLA-CLASS	156		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
GLA-CLASS	156		Body	AHE - Trailer recognition	V	V	V	V	V																												
GLA-CLASS	156		Body	AB - Airbag	V	V	V		V																												
GLA-CLASS	156		Information	Head-up display	V	V			V																												
GLA-CLASS	156		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
GLA-CLASS	156		Information	KAB - Camera cover	V	V			V																												
GLA-CLASS	156		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
GLA-CLASS	156		Information	TV - TV tuner	V	V	V		V																												
GLA-CLASS	156		Information	SOUND - Sound system	V	V	V	V	V																												
GLA-CLASS	156		Information	RFK - Backup camera	V	V	V	V	V																												
GLA-CLASS	156		Information	MFK - Multifunction camera	V	V	V	V	V																												
GLA-CLASS	156		Information	PTS - Parktronic system	V	V	V	V	V																												
GLA-CLASS	156		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
GLA-CLASS	156		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
GLA-CLASS	156		Information	NAV - Navigation module	V	V	V	V	V																												
GLA-CLASS	156		Information	MIF/UCI - Media interface	V	V	V		V																												
GLA-CLASS	156		Information	IC - Instrument cluster	V	V	V	V	V																												
GLA-CLASS	156		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
GLA-CLASS	156		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
GLA-CLASS	156		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
GLA-CLASS	156		Information	AUDIO/COMAND	V	V	V	V	V																												
GLA-CLASS	156		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
GLA-CLASS	156		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
GLA-CLASS	156		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
GLA-CLASS	156		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
GLA-CLASS	156		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
GLA-CLASS	156		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
GLA-CLASS	156		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V		V																												
GLA-CLASS	156		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
GLK-CLASS	204		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V				V						V						V								V
GLK-CLASS	204		Drive	ETC - Electronic transmission control	V	V	V	V	V											V																	
GLK-CLASS	204		Drive	ESM - Electronic selector module	V	V	V	V	V																												
GLK-CLASS	204		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
GLK-CLASS	204		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
GLK-CLASS	204		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
GLK-CLASS	204		Drive	FSCU-R - Control unit fuel pump	V	V	V		V																												
GLK-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
GLK-CLASS	204		Drive	DTR - Distronic	V	V	V		V																												
GLK-CLASS	204		Drive	AMG DRIVE UNIT	V	V	V	V	V																												
GLK-CLASS	204		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
GLK-CLASS	204		Chassis	Suspension	V	V	V	V	V																												
GLK-CLASS	204		Chassis	ES - Electrical power steering	V	V	V		V																												
GLK-CLASS	204		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
GLK-CLASS	204		Body	WSS - Weight sensing system	V	V	V		V																												
GLK-CLASS	204		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
GLK-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
GLK-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
GLK-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
GLK-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
GLK-CLASS	204		Body	OCP - Overhead control panel	V	V	V	V	V																												
GLK-CLASS	204		Body	Multifunction control unit	V	V	V	V	V																												
GLK-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
GLK-CLASS	204		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
GLK-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
GLK-CLASS	204		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
GLK-CLASS	204		Body	CGW - Central gateway	V	V	V		V																												
GLK-CLASS	204		Body	AHE - Trailer recognition	V	V	V	V	V																												
GLK-CLASS	204		Body	AB - Airbag	V	V	V		V																												
GLK-CLASS	204		Information	Head-up display	V	V			V																												
GLK-CLASS	204		Information	AVE-H - Rear audio video unit	V	V			V																												
GLK-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
GLK-CLASS	204		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
GLK-CLASS	204		Information	TV - TV tuner	V	V	V		V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
GLK-CLASS	204		Information	Sound generator for exhaust system	V	V	V		V																												
GLK-CLASS	204		Information	SOUND - Sound system	V	V	V	V	V																												
GLK-CLASS	204		Information	SGR - Radar sensors control unit	V	V	V		V																												
GLK-CLASS	204		Information	360' - Camera	V	V	V		V																												
GLK-CLASS	204		Information	MFK - Multifunction camera	V	V	V	V	V																												
GLK-CLASS	204		Information	RFK - Backup camera	V	V	V	V	V																												
GLK-CLASS	204		Information	PTS - Parktronic system	V	V	V	V	V																												
GLK-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
GLK-CLASS	204		Information	NBR-RF - Right front range radar	V	V			V																												
GLK-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
GLK-CLASS	204		Information	NBR-LF - Left front range radar	V	V			V																												
GLK-CLASS	204		Information	NAV - Navigation module	V	V	V	V	V																												
GLK-CLASS	204		Information	MIF/UCI - Media interface	V	V	V		V																												
GLK-CLASS	204		Information	ICI - InCar Internet	V	V	V		V																												
GLK-CLASS	204		Information	IC - Instrument cluster	V	V	V	V	V																												
GLK-CLASS	204		Information	DVD player	V	V	V	V	V																												
GLK-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
GLK-CLASS	204		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
GLK-CLASS	204		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
GLK-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
GLK-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone	V	V			V																												
GLK-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
GLK-CLASS	204		Information	AUDIO/COMAND	V	V	V	V	V																												
GLK-CLASS	204		Information	AMG Performance Media	V	V	V		V																												
GLK-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
GLK-CLASS	204		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
GLK-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
GLK-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
GLK-CLASS	204		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
GLK-CLASS	204		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
GLK-CLASS	204		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
GLK-CLASS	204		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
GLK-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
GLK-CLASS	204		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
GLC-CLASS	253		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
GLC-CLASS	253		Drive	SG-EM - Power electronics	V	V			V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
GLC-CLASS	253		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
GLC-CLASS	253		Drive	DTR - Distronic	V	V	V		V																												
GLC-CLASS	253		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
GLC-CLASS	253		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
GLC-CLASS	253		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
GLC-CLASS	253		Drive	ETC - Electronic transmission control	V	V	V		V												V																
GLC-CLASS	253		Chassis	TPM - Tire pressure monitor	V	V			V																												
GLC-CLASS	253		Chassis	AIRMATIC PLUS	V	V			V																												
GLC-CLASS	253		Chassis	ES - Electrical power steering	V	V	V		V																												
GLC-CLASS	253		Chassis	Suspension	V	V			V																												
GLC-CLASS	253		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V							V																					
GLC-CLASS	253		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
GLC-CLASS	253		Body	AHE - Trailer recognition	V	V			V																												
GLC-CLASS	253		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
GLC-CLASS	253		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
GLC-CLASS	253		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
GLC-CLASS	253		Body	AB - Airbag	V	V			V																												
GLC-CLASS	253		Body	Multifunction control unit	V	V			V																												
GLC-CLASS	253		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
GLC-CLASS	253		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
GLC-CLASS	253		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V														V														
GLC-CLASS	253		Body	SG-AWF - Collision prevention assist	V	V			V																												
GLC-CLASS	253		Body	EZS/EIS - Electronic ignition lock	V	V			V																												
GLC-CLASS	253		Body	BNS/BMS - Battery sensor	V	V	V		V																												
GLC-CLASS	253		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
GLC-CLASS	253		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
GLC-CLASS	253		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
GLC-CLASS	253		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
GLC-CLASS	253		Seat/Door	PSD/MSC - Sliding roof control	V	V			V																												
GLC-CLASS	253		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
GLC-CLASS	253		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
GLC-CLASS	253		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
GLC-CLASS	253		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
GLC-CLASS	253		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
GLC-CLASS	253		Information	TPAD - Touchpad	V	V	V	V	V																												
GLC-CLASS	253		Information	DAB/SDAR - Digital/Satellite radio	V	V			V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
GLC-CLASS	253		Information	360' - Camera	V	V	V	V	V																												
GLC-CLASS	253		Information	Sound generator for exhaust system	V	V			V																												
GLC-CLASS	253		Information	SOUND - Sound system	V	V			V																												
GLC-CLASS	253		Information	RFK - Backup camera	V	V	V	V	V																												
GLC-CLASS	253		Information	SGR - Radar sensors control unit	V	V	V		V																												
GLC-CLASS	253		Information	PTS - Parktronic system	V	V	V	V	V																												
GLC-CLASS	253		Information	NBR-RF - Right front range radar					V																												
GLC-CLASS	253		Information	NBR-LF - Left front range radar					V																												
GLC-CLASS	253		Information	MFK - Multifunction camera	V	V	V	V	V																												
GLC-CLASS	253		Information	IC - Instrument cluster	V	V	V	V	V																												
GLC-CLASS	253		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
GLC-CLASS	253		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
GLC-CLASS	253		Information	Head-up display	V	V		V	V																												
GLC-CLASS	253		Information	AUDIO/COMAND	V	V			V																												
GLC-CLASS	253		Information	SG-MSND - Engine sound	V	V			V																												
GLC-CLASS	253		Information	ZAN - Audio/COMAND display	V	V			V																												
GLC-CLASS	253		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
GLC-CLASS	253		Information	KAB - Camera cover	V	V	V	V	V																												
GLC-CLASS	253		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
GLC-CLASS	253		Information	AMG Performance Media	V	V			V																												
GLC-CLASS	253		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
GLE-CLASS	292		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
GLE-CLASS	292		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
GLE-CLASS	292		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
GLE-CLASS	292		Drive	DTR - Distronic	V	V	V		V																												
GLE-CLASS	292		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
GLE-CLASS	292		Drive	ETC - Electronic transmission control	V	V	V	V	V												V																
GLE-CLASS	292		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
GLE-CLASS	292		Chassis	FWGW - Chassis gateway	V	V	V		V																												
GLE-CLASS	292		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
GLE-CLASS	292		Chassis	ES - Electrical power steering	V	V	V		V																												
GLE-CLASS	292		Chassis	EFB - Electric parking brake	V	V	V		V																												
GLE-CLASS	292		Chassis	Suspension	V	V	V	V	V																												
GLE-CLASS	292		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
GLE-CLASS	292		Body	AHE - Trailer recognition	V	V	V	V	V																												
GLE-CLASS	292		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
GLE-CLASS	292		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
GLE-CLASS	292		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
GLE-CLASS	292		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
GLE-CLASS	292		Body	AB - Airbag	V	V	V		V																												
GLE-CLASS	292		Body	Multifunction control unit	V	V	V	V	V																												
GLE-CLASS	292		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
GLE-CLASS	292		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
GLE-CLASS	292		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
GLE-CLASS	292		Body	SG-AWF - Collision prevention assist	V	V	V		V																												
GLE-CLASS	292		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
GLE-CLASS	292		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
GLE-CLASS	292		Information	TPAD - Touchpad	V	V	V	V	V																												
GLE-CLASS	292		Information	DAB/SDAR - Digital/Satellite radio	V	V			V																												
GLE-CLASS	292		Information	360' - Camera	V	V	V		V																												
GLE-CLASS	292		Information	SOUND - Sound system	V	V			V																												
GLE-CLASS	292		Information	RFK - Backup camera	V	V	V	V	V																												
GLE-CLASS	292		Information	SGR - Radar sensors control unit	V	V	V		V																												
GLE-CLASS	292		Information	PTS - Parktronic system	V	V	V	V	V																												
GLE-CLASS	292		Information	MFK - Multifunction camera	V	V	V	V	V																												
GLE-CLASS	292		Information	NBR-RF - Right front range radar	V	V			V																												
GLE-CLASS	292		Information	NBR-LF - Left front range radar	V	V			V																												
GLE-CLASS	292		Information	IC - Instrument cluster	V	V	V	V	V																												
GLE-CLASS	292		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
GLE-CLASS	292		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
GLE-CLASS	292		Information	Head-up display	V	V			V																												
GLE-CLASS	292		Information	AUDIO/COMAND	V	V			V																												
GLE-CLASS	292		Information	AVE-H - Rear audio video unit	V	V			V																												
GLE-CLASS	292		Information	DVD player	V	V	V	V	V																												
GLE-CLASS	292		Information	SG-MSND - Engine sound	V	V			V																												
GLE-CLASS	292		Information	ZAN - Audio/COMAND display	V	V			V																												
GLE-CLASS	292		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
GLE-CLASS	292		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
GLE-CLASS	292		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
GLE-CLASS	292		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
GLE-CLASS	292		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
GLE-CLASS	292		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
GLE-CLASS	292		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
GLE-CLASS	292		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
GLE-CLASS	292		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																												
GLE-CLASS	292		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																												
GLE-CLASS	292		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
GLE-CLASS	292		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
GLE-CLASS	292		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
GLE-CLASS	292		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
GLE-CLASS	292		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V		V																												
GLE-CLASS	292		Air Conditioning	HBF - Rear control panel	V	V	V		V																												
GLE-CLASS	292		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
GL-CLASS	164		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V					V		V				V		V					V							V
GL-CLASS	164		Drive	ETC - Electronic transmission control	V	V	V	V	V												V																
GL-CLASS	164		Drive	VG - Transfer case	V	V	V	V	V																												
GL-CLASS	164		Drive	SG-EM-B - Electric motor control unit B	V	V	V		V																												
GL-CLASS	164		Drive	SG-EM-A - Electric motor control unit A	V	V	V		V																												
GL-CLASS	164		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
GL-CLASS	164		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
GL-CLASS	164		Drive	HSG - Hybrid control unit	V	V	V	V	V							V																					
GL-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
GL-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter	V	V			V																												
GL-CLASS	164		Drive	DTR - Distronic	V	V	V		V																												
GL-CLASS	164		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
GL-CLASS	164		Chassis	Suspension	V	V	V	V	V																												
GL-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle	V	V	V		V																												
GL-CLASS	164		Chassis	ES - Electrical power steering	V	V	V		V																												
GL-CLASS	164		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
GL-CLASS	164		Body	WSS - Weight sensing system	V	V	V		V																												
GL-CLASS	164		Body	UCP - Upper control panel	V	V	V	V	V																												
GL-CLASS	164		Body	System diagnosis	V	V			V																												
GL-CLASS	164		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
GL-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
GL-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V																												
GL-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V	V	V																												
GL-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V	V	V																												
GL-CLASS	164		Body	OCP - Overhead control panel	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
GL-CLASS	164		Body	LCP/HBF - Lower/Rear control panel	V	V	V	V	V																												
GL-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
GL-CLASS	164		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
GL-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
GL-CLASS	164		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
GL-CLASS	164		Body	CGW - Central gateway	V	V			V																												
GL-CLASS	164		Body	AB - Airbag	V	V	V		V																												
GL-CLASS	164		Information	TV - TV tuner	V	V			V																												
GL-CLASS	164		Information	SOUND - Sound system	V	V	V	V	V																												
GL-CLASS	164		Information	RFK - Backup camera	V	V	V		V																												
GL-CLASS	164		Information	PTS - Parktronic system	V	V	V	V	V																												
GL-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V	V		V																												
GL-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
GL-CLASS	164		Information	NAV - Navigation module	V	V			V																												
GL-CLASS	164		Information	MIF/UCI - Media interface	V	V	V		V																												
GL-CLASS	164		Information	IC - Instrument cluster	V	V	V	V	V																												
GL-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
GL-CLASS	164		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
GL-CLASS	164		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
GL-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio	V	V	V		V																												
GL-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone	V	V	V		V																												
GL-CLASS	164		Information	CM - Compass module	V	V	V		V																												
GL-CLASS	164		Information	AVE-H - Rear audio video unit	V	V	V	V	V																												
GL-CLASS	164		Information	AUDIO/COMAND	V	V	V	V	V																												
GL-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System	V	V	V		V																												
GL-CLASS	164		Information	ASSYST Active Service System	V	V	V		V																										V		
GL-CLASS	164		Information	AGW - Audio gateway	V	V	V	V	V																												
GL-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module	V	V	V	V	V																												
GL-CLASS	164		Seat/Door	HS - Seat heater	V	V	V	V	V																												
GL-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
GL-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
GL-CLASS	164		Seat/Door	ERA - Electric fold down backrest system	V	V	V	V	V																												
GL-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																			V									
GL-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V	V	V																												
GL-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																			V									
GL-CLASS	164		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
GL-CLASS	164		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
GL-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
GL-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor	V	V	V		V																												
GL-CLASS	164		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
GL-CLASS	166		Drive	SG-EM - Power electronics	V	V			V																												
GL-CLASS	166		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
GL-CLASS	166		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
GL-CLASS	166		Drive	ETC - Electronic transmission control	V	V	V	V	V												V																
GL-CLASS	166		Drive	VG - Transfer case	V	V	V		V																												
GL-CLASS	166		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
GL-CLASS	166		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
GL-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
GL-CLASS	166		Drive	DTR - Distronic	V	V	V		V																												
GL-CLASS	166		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
GL-CLASS	166		Chassis	Suspension	V	V	V	V	V																												
GL-CLASS	166		Chassis	ES - Electrical power steering	V	V	V		V																												
GL-CLASS	166		Chassis	EFB - Electric parking brake	V	V	V		V																												
GL-CLASS	166		Chassis	FWGW - Chassis gateway	V	V	V		V																												
GL-CLASS	166		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
GL-CLASS	166		Body	SG-AWF - Collision prevention assist	V	V	V		V																												
GL-CLASS	166		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
GL-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
GL-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
GL-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
GL-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
GL-CLASS	166		Body	Multifunction control unit	V	V	V	V	V																												
GL-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
GL-CLASS	166		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
GL-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
GL-CLASS	166		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
GL-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
GL-CLASS	166		Body	AHE - Trailer recognition	V	V	V	V	V																												
GL-CLASS	166		Body	AB - Airbag	V	V	V		V																												
GL-CLASS	166		Information	Sound generator for exhaust system	V	V			V																												
GL-CLASS	166		Information	Head-up display	V	V			V																												
GL-CLASS	166		Information	AVE-H - Rear audio video unit	V	V			V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
GL-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
GL-CLASS	166		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
GL-CLASS	166		Information	TV - TV tuner	V	V	V		V																												
GL-CLASS	166		Information	SOUND - Sound system	V	V	V	V	V																												
GL-CLASS	166		Information	SGR - Radar sensors control unit	V	V	V		V																												
GL-CLASS	166		Information	360' - Camera	V	V	V		V																												
GL-CLASS	166		Information	RFK - Backup camera	V	V	V	V	V																												
GL-CLASS	166		Information	MFK - Multifunction camera	V	V	V	V	V																												
GL-CLASS	166		Information	PTS - Parktronic system	V	V	V	V	V																												
GL-CLASS	166		Information	NSA - Night View Assist	V	V	V	V	V																												
GL-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
GL-CLASS	166		Information	NBR-RF - Right front range radar	V	V			V																												
GL-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
GL-CLASS	166		Information	NBR-LF - Left front range radar	V	V			V																												
GL-CLASS	166		Information	NAV - Navigation module	V	V	V		V																												
GL-CLASS	166		Information	MIF/UCI - Media interface	V	V	V		V																												
GL-CLASS	166		Information	IC - Instrument cluster	V	V	V	V	V																												
GL-CLASS	166		Information	DVD player	V	V	V	V	V																												
GL-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
GL-CLASS	166		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
GL-CLASS	166		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
GL-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
GL-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
GL-CLASS	166		Information	AUDIO/COMAND	V	V	V	V	V																												
GL-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
GL-CLASS	166		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
GL-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
GL-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
GL-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																												
GL-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V		V																												
GL-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																												
GL-CLASS	166		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
GL-CLASS	166		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
GL-CLASS	166		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
GL-CLASS	166		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
GL-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V		V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
GL-CLASS	166		Air Conditioning	HBF - Rear control panel	V	V	V		V																												
GL-CLASS	166		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
M-CLASS	163		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V											V						V											
M-CLASS	163		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
M-CLASS	163		Drive	ESM - Electronic selector module	V	V	V	V	V																												
M-CLASS	163		Drive	VG - Transfer case	V		V		V																												
M-CLASS	163		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
M-CLASS	163		Chassis	VP - Vacuum pump brake booster	V	V	V	V	V																												
M-CLASS	163		Chassis	BAS - Brake assist	V	V			V																												
M-CLASS	163		Body	Headlamp/Headlamp-L - Headlamp control unit	V				V																												
M-CLASS	163		Body	AB - Airbag	V	V	V		V																												
M-CLASS	163		Body	AAM - All activity module	V				V																												
M-CLASS	163		Information	PTS - Parktronic system	V	V	V	V	V																												
M-CLASS	163		Information	IC - Instrument cluster	V	V	V	V	V																		V										
M-CLASS	163		Information	DTA - Mbrace or TELEAID/GPS Box	V	V		V	V												V																
M-CLASS	163		Information	AUDIO/COMAND	V	V		V	V																												
M-CLASS	163		Air Conditioning	AAC - Automatic air conditioning	V		V	V	V																												
M-CLASS	163		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
M-CLASS	164		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V					V		V				V		V					V						V
M-CLASS	164		Drive	ETC - Electronic transmission control	V	V	V	V	V												V																
M-CLASS	164		Drive	VG - Transfer case	V	V	V	V	V																												
M-CLASS	164		Drive	SG-EM-B - Electric motor control unit B	V	V	V		V																												
M-CLASS	164		Drive	SG-EM-A - Electric motor control unit A	V	V	V		V																												
M-CLASS	164		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
M-CLASS	164		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
M-CLASS	164		Drive	HSG - Hybrid control unit	V	V	V	V	V							V																					
M-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
M-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter	V	V			V																												
M-CLASS	164		Drive	DTR - Distronic	V	V	V		V																												
M-CLASS	164		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
M-CLASS	164		Chassis	Suspension	V	V	V	V	V																												
M-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle	V	V	V		V																												
M-CLASS	164		Chassis	ES - Electrical power steering	V	V	V		V																												
M-CLASS	164		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
M-CLASS	164		Body	WSS - Weight sensing system	V	V	V		V																												
M-CLASS	164		Body	UCP - Upper control panel	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
M-CLASS	164		Body	System diagnosis	V	V			V																												
M-CLASS	164		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
M-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
M-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V																												
M-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V	V	V																												
M-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V	V	V																												
M-CLASS	164		Body	OCP - Overhead control panel	V	V	V	V	V																												
M-CLASS	164		Body	LCP/HBF - Lower/Rear control panel	V	V	V	V	V																												
M-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
M-CLASS	164		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
M-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
M-CLASS	164		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
M-CLASS	164		Body	CGW - Central gateway	V	V			V																												
M-CLASS	164		Body	AB - Airbag	V	V	V		V																												
M-CLASS	164		Information	TV - TV tuner	V	V			V																												
M-CLASS	164		Information	SOUND - Sound system	V	V	V	V	V																												
M-CLASS	164		Information	RFK - Backup camera	V	V	V		V																												
M-CLASS	164		Information	PTS - Parktronic system	V	V	V	V	V																												
M-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V	V		V																												
M-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
M-CLASS	164		Information	NAV - Navigation module	V	V			V																												
M-CLASS	164		Information	MIF/UCI - Media interface	V	V	V		V																												
M-CLASS	164		Information	IC - Instrument cluster	V	V	V	V	V																												
M-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
M-CLASS	164		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
M-CLASS	164		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
M-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio	V	V	V		V																												
M-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone	V	V	V		V																												
M-CLASS	164		Information	CM - Compass module	V	V	V		V																												
M-CLASS	164		Information	AVE-H - Rear audio video unit	V	V	V	V	V																												
M-CLASS	164		Information	AUDIO/COMAND	V	V	V	V	V																												
M-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System	V	V	V		V																												
M-CLASS	164		Information	ASSYST Active Service System	V	V	V		V																										V		
M-CLASS	164		Information	AGW - Audio gateway	V	V	V	V	V																												
M-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module	V	V	V	V	V																												
M-CLASS	164		Seat/Door	HS - Seat heater	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
M-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
M-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
M-CLASS	164		Seat/Door	ERA - Electric fold down backrest system	V	V	V	V	V																												
M-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																				V								
M-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V	V	V																												
M-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																				V								
M-CLASS	164		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
M-CLASS	164		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
M-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
M-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor	V	V	V		V																												
M-CLASS	164		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
M-CLASS	166		Drive	SG-EM - Power electronics	V	V			V																												
M-CLASS	166		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
M-CLASS	166		Drive	ETC - Electronic transmission control	V	V	V	V	V												V																
M-CLASS	166		Drive	VG - Transfer case	V	V	V		V																												
M-CLASS	166		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
M-CLASS	166		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
M-CLASS	166		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
M-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
M-CLASS	166		Drive	DTR - Distronic	V	V	V		V																												
M-CLASS	166		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
M-CLASS	166		Chassis	Suspension	V	V	V	V	V																												
M-CLASS	166		Chassis	ES - Electrical power steering	V	V	V		V																												
M-CLASS	166		Chassis	EFB - Electric parking brake	V	V	V		V																												
M-CLASS	166		Chassis	FWGW - Chassis gateway	V	V	V		V																												
M-CLASS	166		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
M-CLASS	166		Body	SG-AWF - Collision prevention assist	V	V	V		V																												
M-CLASS	166		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
M-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
M-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
M-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
M-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
M-CLASS	166		Body	Multifunction control unit	V	V	V	V	V																												
M-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
M-CLASS	166		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
M-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
M-CLASS	166		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
M-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
M-CLASS	166		Body	AHE - Trailer recognition	V	V	V	V	V																												
M-CLASS	166		Body	AB - Airbag	V	V	V		V																												
M-CLASS	166		Information	Sound generator for exhaust system	V	V			V																												
M-CLASS	166		Information	Head-up display	V	V			V																												
M-CLASS	166		Information	AVE-H - Rear audio video unit	V	V			V																												
M-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
M-CLASS	166		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
M-CLASS	166		Information	TV - TV tuner	V	V	V		V																												
M-CLASS	166		Information	SOUND - Sound system	V	V	V	V	V																												
M-CLASS	166		Information	SGR - Radar sensors control unit	V	V	V		V																												
M-CLASS	166		Information	360' - Camera	V	V	V		V																												
M-CLASS	166		Information	RFK - Backup camera	V	V	V	V	V																												
M-CLASS	166		Information	MFK - Multifunction camera	V	V	V	V	V																												
M-CLASS	166		Information	PTS - Parktronic system	V	V	V	V	V																												
M-CLASS	166		Information	NSA - Night View Assist	V	V	V	V	V																												
M-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
M-CLASS	166		Information	NBR-RF - Right front range radar	V	V			V																												
M-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
M-CLASS	166		Information	NBR-LF - Left front range radar	V	V			V																												
M-CLASS	166		Information	NAV - Navigation module	V	V	V		V																												
M-CLASS	166		Information	MIF/UCI - Media interface	V	V	V		V																												
M-CLASS	166		Information	IC - Instrument cluster	V	V	V	V	V																												
M-CLASS	166		Information	DVD player	V	V	V	V	V																												
M-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
M-CLASS	166		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
M-CLASS	166		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
M-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
M-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
M-CLASS	166		Information	AUDIO/COMAND	V	V	V	V	V																												
M-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
M-CLASS	166		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
M-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
M-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
M-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
M-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V		V																												
M-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																												
M-CLASS	166		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
M-CLASS	166		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
M-CLASS	166		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
M-CLASS	166		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
M-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V		V																												
M-CLASS	166		Air Conditioning	HBF - Rear control panel	V	V	V		V																												
M-CLASS	166		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
R-CLASS	251		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V					V		V				V		V					V							V
R-CLASS	251		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
R-CLASS	251		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
R-CLASS	251		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
R-CLASS	251		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
R-CLASS	251		Drive	DTR - Distronic	V	V	V		V																												
R-CLASS	251		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
R-CLASS	251		Chassis	Suspension	V	V	V	V	V																												
R-CLASS	251		Chassis	ES - Electrical power steering	V	V	V		V																												
R-CLASS	251		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
R-CLASS	251		Body	WSS - Weight sensing system	V	V	V		V																												
R-CLASS	251		Body	UCP - Upper control panel	V	V	V	V	V																												
R-CLASS	251		Body	System diagnosis	V	V			V																												
R-CLASS	251		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
R-CLASS	251		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
R-CLASS	251		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V																												
R-CLASS	251		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V	V	V																												
R-CLASS	251		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V	V	V																												
R-CLASS	251		Body	OCP - Overhead control panel	V	V	V	V	V																												
R-CLASS	251		Body	LCP/HBF - Lower/Rear control panel	V	V	V	V	V																												
R-CLASS	251		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
R-CLASS	251		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
R-CLASS	251		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
R-CLASS	251		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
R-CLASS	251		Body	CGW - Central gateway	V	V			V																												
R-CLASS	251		Body	AB - Airbag	V	V	V		V																												
R-CLASS	251		Information	TV - TV tuner	V	V			V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
R-CLASS	251		Information	SOUND - Sound system	V	V	V	V	V																												
R-CLASS	251		Information	RFK - Backup camera	V	V	V		V																												
R-CLASS	251		Information	PTS - Parktronic system	V	V	V	V	V																												
R-CLASS	251		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V	V		V																												
R-CLASS	251		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
R-CLASS	251		Information	NAV - Navigation module	V	V			V																												
R-CLASS	251		Information	MIF/UCI - Media interface	V	V	V		V																												
R-CLASS	251		Information	IC - Instrument cluster	V	V	V	V	V																												
R-CLASS	251		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
R-CLASS	251		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
R-CLASS	251		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
R-CLASS	251		Information	DAB/SDAR - Digital/Satellite radio	V	V	V		V																												
R-CLASS	251		Information	CTEL/TEL - Cellular/Mobile telephone	V	V	V		V																												
R-CLASS	251		Information	CM - Compass module	V	V	V		V																												
R-CLASS	251		Information	AVE-H - Rear audio video unit	V	V	V	V	V																												
R-CLASS	251		Information	AUDIO/COMAND	V	V	V	V	V																												
R-CLASS	251		Information	ASSYST PLUS - PLUS Active Service System	V	V	V		V																												
R-CLASS	251		Information	ASSYST Active Service System	V	V	V		V																									V			
R-CLASS	251		Information	AGW - Audio gateway	V	V	V	V	V																												
R-CLASS	251		Seat/Door	REDC/RWT - Rear end door control module	V	V	V	V	V																												
R-CLASS	251		Seat/Door	HS - Seat heater	V	V	V	V	V																												
R-CLASS	251		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
R-CLASS	251		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
R-CLASS	251		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																			V									
R-CLASS	251		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V	V	V																												
R-CLASS	251		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																			V									
R-CLASS	251		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
R-CLASS	251		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
R-CLASS	251		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
R-CLASS	251		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
CLA-CLASS	117		Drive	VG - Transfer case	V	V			V																												
CLA-CLASS	117		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
CLA-CLASS	117		Drive	ETC - Electronic transmission control	V	V	V		V												V																
CLA-CLASS	117		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
CLA-CLASS	117		Drive	DTR - Distronic	V	V	V		V																												
CLA-CLASS	117		Drive	DSI - Direct select interface	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
CLA-CLASS	117		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
CLA-CLASS	117		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
CLA-CLASS	117		Chassis	ES - Electrical power steering	V	V	V		V																												
CLA-CLASS	117		Chassis	EFB - Electric parking brake	V	V	V		V																												
CLA-CLASS	117		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
CLA-CLASS	117		Body	SG-AWF - Collision prevention assist	V	V	V		V																												
CLA-CLASS	117		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
CLA-CLASS	117		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
CLA-CLASS	117		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
CLA-CLASS	117		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
CLA-CLASS	117		Body	Multifunction control unit	V	V	V	V	V																												
CLA-CLASS	117		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
CLA-CLASS	117		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
CLA-CLASS	117		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
CLA-CLASS	117		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
CLA-CLASS	117		Body	AHE - Trailer recognition	V	V	V	V	V																												
CLA-CLASS	117		Body	AB - Airbag	V	V	V		V																												
CLA-CLASS	117		Information	Head-up display	V	V			V																												
CLA-CLASS	117		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
CLA-CLASS	117		Information	KAB - Camera cover	V	V			V																												
CLA-CLASS	117		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
CLA-CLASS	117		Information	TV - TV tuner	V	V	V		V																												
CLA-CLASS	117		Information	SOUND - Sound system	V	V	V	V	V																												
CLA-CLASS	117		Information	RFK - Backup camera	V	V	V	V	V																												
CLA-CLASS	117		Information	MFK - Multifunction camera	V	V	V	V	V																												
CLA-CLASS	117		Information	PTS - Parktronic system	V	V	V	V	V																												
CLA-CLASS	117		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
CLA-CLASS	117		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
CLA-CLASS	117		Information	NAV - Navigation module	V	V	V	V	V																												
CLA-CLASS	117		Information	MIF/UCI - Media interface	V	V	V		V																												
CLA-CLASS	117		Information	IC - Instrument cluster	V	V	V	V	V																												
CLA-CLASS	117		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
CLA-CLASS	117		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
CLA-CLASS	117		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
CLA-CLASS	117		Information	AUDIO/COMAND	V	V	V	V	V																												
CLA-CLASS	117		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
CLA-CLASS	117		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
CLA-CLASS	117		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
CLA-CLASS	117		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
CLA-CLASS	117		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
CLA-CLASS	117		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
CLA-CLASS	117		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V		V																												
CLA-CLASS	117		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
CLK-CLASS	208		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V																								
CLK-CLASS	208		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
CLK-CLASS	208		Drive	ESM - Electronic selector module	V	V	V	V	V																												
CLK-CLASS	208		Chassis	PSE - Pneumatic system equipment	V				V																												
CLK-CLASS	208		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
CLK-CLASS	208		Chassis	VP - Vacuum pump brake booster	V	V	V	V	V																												
CLK-CLASS	208		Chassis	BAS - Brake assist	V	V	V		V																												
CLK-CLASS	208		Body	LCP/HBF - Lower/Rear control panel	V		V	V	V																												
CLK-CLASS	208		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V				V																												
CLK-CLASS	208		Body	EZS/EIS - Electronic ignition lock	V		V		V																												
CLK-CLASS	208		Body	OCP - Overhead control panel	V		V		V																												
CLK-CLASS	208		Body	AB - Airbag	V		V		V																												
CLK-CLASS	208		Information	TV - TV tuner	V	V		V	V																												
CLK-CLASS	208		Information	PTS - Parktronic system	V	V	V	V	V																												
CLK-CLASS	208		Information	NAV - Navigation module	V	V			V																												
CLK-CLASS	208		Information	IC - Instrument cluster	V	V	V	V	V																		V										
CLK-CLASS	208		Information	DTA - Mbrace or TELEAID/GPS Box	V	V		V	V												V																
CLK-CLASS	208		Information	AUDIO/COMAND	V	V		V	V																												
CLK-CLASS	208		Information	APS - Auto pilot system	V	V			V																												
CLK-CLASS	208		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
CLK-CLASS	208		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
CLK-CLASS	208		Seat/Door	DCM-FR - Door control module front right	V				V																												
CLK-CLASS	208		Seat/Door	DCM-FL - Door control module front left	V				V																												
CLK-CLASS	208		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V				V																												
CLK-CLASS	208		Seat/Door	ESA Driver - Electric seat adjustment Driver	V				V																												
CLK-CLASS	209		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V							V			V		V					V							
CLK-CLASS	209		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
CLK-CLASS	209		Drive	ESM - Electronic selector module	V	V	V	V	V																												
CLK-CLASS	209		Drive	DTR - Distronic	V	V	V		V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
CLK-CLASS	209		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
CLK-CLASS	209		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
CLK-CLASS	209		Body	WSS - Weight sensing system	V	V	V		V																												
CLK-CLASS	209		Body	UCP - Upper control panel	V	V	V	V	V																												
CLK-CLASS	209		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
CLK-CLASS	209		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
CLK-CLASS	209		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V																												
CLK-CLASS	209		Body	RCM - Rear control module	V	V	V	V	V																												
CLK-CLASS	209		Body	OCP - Overhead control panel	V	V	V	V	V																												
CLK-CLASS	209		Body	Multifunction control unit	V	V	V	V	V																												
CLK-CLASS	209		Body	LCP/HBF - Lower/Rear control panel	V	V	V	V	V																												
CLK-CLASS	209		Body	Headlamp-R - Headlamp control unit	V	V	V		V																												
CLK-CLASS	209		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
CLK-CLASS	209		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
CLK-CLASS	209		Body	BNS/BMS - Battery sensor	V	V	V	V	V																												
CLK-CLASS	209		Body	AHE - Trailer recognition	V	V	V	V	V																												
CLK-CLASS	209		Body	AB - Airbag	V	V	V		V																												
CLK-CLASS	209		Information	TV - TV tuner	V	V		V	V																												
CLK-CLASS	209		Information	PTS - Parktronic system	V	V	V	V	V																												
CLK-CLASS	209		Information	NAV - Navigation module	V	V			V																												
CLK-CLASS	209		Information	IC - Instrument cluster	V	V	V	V	V																												
CLK-CLASS	209		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V	V	V												V																
CLK-CLASS	209		Information	AUDIO/COMAND	V	V		V	V																												
CLK-CLASS	209		Information	AGW - Audio gateway	V	V	V	V	V																												
CLK-CLASS	209		Seat/Door	RVC/VDS - Convertible roof control	V	V	V	V	V																												
CLK-CLASS	209		Seat/Door	REDC/RWT - Rear end door control module	V	V	V	V	V																												
CLK-CLASS	209		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
CLK-CLASS	209		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
CLK-CLASS	209		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
CLK-CLASS	209		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
CLK-CLASS	209		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
CLK-CLASS	209		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
CLS-CLASS	219		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V						V			V		V				V								
CLS-CLASS	219		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
CLS-CLASS	219		Drive	ESM - Electronic selector module	V	V	V	V	V																												
CLS-CLASS	219		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V		V																								V			

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
CLS-CLASS	219		Drive	DTR - Distronic	V	V	V		V																												
CLS-CLASS	219		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
CLS-CLASS	219		Chassis	Suspension	V	V	V	V	V																												
CLS-CLASS	219		Chassis	SBC - Sensotronic Brake Control	V	V	V		V																												
CLS-CLASS	219		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
CLS-CLASS	219		Body	WSS - Weight sensing system	V	V	V		V																												
CLS-CLASS	219		Body	UCP - Upper control panel	V	V	V	V	V																												
CLS-CLASS	219		Body	System diagnosis	V	V			V																												
CLS-CLASS	219		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
CLS-CLASS	219		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
CLS-CLASS	219		Body	SAM-P- Passenger-side signal acquisition and actuation module	V	V	V	V	V																												
CLS-CLASS	219		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V																												
CLS-CLASS	219		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V	V	V																												
CLS-CLASS	219		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V	V	V																												
CLS-CLASS	219		Body	OCP - Overhead control panel	V	V	V	V	V																												
CLS-CLASS	219		Body	LCP/HBF - Lower/Rear control panel	V	V	V	V	V																												
CLS-CLASS	219		Body	LAE [LAA] - Loading floor automatically extendable	V	V	V	V	V																												
CLS-CLASS	219		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
CLS-CLASS	219		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
CLS-CLASS	219		Body	CGW - Central gateway	V	V			V																												
CLS-CLASS	219		Body	BNS/BMS - Battery sensor	V	V	V	V	V																												
CLS-CLASS	219		Body	AB - Airbag	V	V	V		V																												
CLS-CLASS	219		Information	TV - TV tuner	V	V			V																												
CLS-CLASS	219		Information	SOUND - Sound system	V	V	V	V	V																												
CLS-CLASS	219		Information	PTS - Parktronic system	V	V	V	V	V																												
CLS-CLASS	219		Information	MIF/UCI - Media interface	V	V	V		V																												
CLS-CLASS	219		Information	IC - Instrument cluster	V	V	V	V	V																												
CLS-CLASS	219		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
CLS-CLASS	219		Information	DAB/SDAR - Digital/Satellite radio	V	V	V		V																												
CLS-CLASS	219		Information	CTEL/TEL - Cellular/Mobile telephone	V	V	V		V																												
CLS-CLASS	219		Information	AUDIO/COMAND	V	V	V	V	V																												
CLS-CLASS	219		Information	ASSYST PLUS - PLUS Active Service System	V	V	V		V																												
CLS-CLASS	219		Information	ASSYST Active Service System	V	V	V		V																										V		
CLS-CLASS	219		Information	AGW - Audio gateway	V	V	V	V	V																												
CLS-CLASS	219		Seat/Door	REDC/RWT - Rear end door control module	V	V	V	V	V																												
CLS-CLASS	219		Seat/Door	HS - Seat heater	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
CLS-CLASS	219		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
CLS-CLASS	219		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
CLS-CLASS	219		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																				V								
CLS-CLASS	219		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V	V	V																												
CLS-CLASS	219		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																				V								
CLS-CLASS	219		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
CLS-CLASS	219		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
CLS-CLASS	219		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
CLS-CLASS	219		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
CLS-CLASS	219		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
CLS-CLASS	219		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
CLS-CLASS	218		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V					V						V							V						V
CLS-CLASS	218		Drive	ETC - Electronic transmission control	V	V	V	V	V												V																
CLS-CLASS	218		Drive	ESM - Electronic selector module	V	V	V	V	V																												
CLS-CLASS	218		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
CLS-CLASS	218		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
CLS-CLASS	218		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
CLS-CLASS	218		Drive	DTR - Distronic	V	V	V		V																												
CLS-CLASS	218		Drive	DSI - Direct select interface	V	V	V	V	V																												
CLS-CLASS	218		Drive	AMG DRIVE UNIT	V	V	V	V	V																												
CLS-CLASS	218		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
CLS-CLASS	218		Chassis	Suspension	V	V	V	V	V																												
CLS-CLASS	218		Chassis	ES - Electrical power steering	V	V	V		V																												
CLS-CLASS	218		Chassis	FWGW - Chassis gateway	V	V	V		V																												
CLS-CLASS	218		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
CLS-CLASS	218		Body	SG-LML-VR - LED matrix of right front lamp unit	V	V			V																												
CLS-CLASS	218		Body	SG-LML-VL - LED matrix of left front lamp unit	V	V			V																												
CLS-CLASS	218		Body	WSS - Weight sensing system	V	V	V		V																												
CLS-CLASS	218		Body	SG-AWF - Collision prevention assist	V	V	V		V																												
CLS-CLASS	218		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
CLS-CLASS	218		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
CLS-CLASS	218		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
CLS-CLASS	218		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
CLS-CLASS	218		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
CLS-CLASS	218		Body	OCP - Overhead control panel	V	V	V	V	V																												
CLS-CLASS	218		Body	Multifunction control unit	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
CLS-CLASS	218		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
CLS-CLASS	218		Body	HSW/LRH - Steering wheel heater	V	V	V		V																												
CLS-CLASS	218		Body	HS/AIRSCARF - Seat heater/Air scarf system	V	V	V	V	V																												
CLS-CLASS	218		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
CLS-CLASS	218		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
CLS-CLASS	218		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
CLS-CLASS	218		Body	CGW - Central gateway	V	V	V		V																												
CLS-CLASS	218		Body	AHE - Trailer recognition	V	V	V	V	V																												
CLS-CLASS	218		Body	AB - Airbag	V	V	V		V																												
CLS-CLASS	218		Information	360' - Camera	V	V	V		V																												
CLS-CLASS	218		Information	AVE-H - Rear audio video unit	V	V			V																												
CLS-CLASS	218		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
CLS-CLASS	218		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
CLS-CLASS	218		Information	TV - TV tuner	V	V	V		V																												
CLS-CLASS	218		Information	SOUND - Sound system	V	V	V	V	V																												
CLS-CLASS	218		Information	SGR - Radar sensors control unit	V	V	V		V																												
CLS-CLASS	218		Information	MFK - Multifunction camera	V	V	V	V	V																												
CLS-CLASS	218		Information	RFK - Backup camera	V	V	V	V	V																												
CLS-CLASS	218		Information	PTS - Parktronic system	V	V	V	V	V																												
CLS-CLASS	218		Information	NSA - Night View Assist	V	V	V	V	V																												
CLS-CLASS	218		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
CLS-CLASS	218		Information	NBR-RF - Right front range radar	V	V			V																												
CLS-CLASS	218		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
CLS-CLASS	218		Information	NBR-LF - Left front range radar	V	V			V																												
CLS-CLASS	218		Information	NAV - Navigation module	V	V	V	V	V																												
CLS-CLASS	218		Information	MIF/UCI - Media interface	V	V	V		V																												
CLS-CLASS	218		Information	ICI - InCar Internet	V	V	V		V																												
CLS-CLASS	218		Information	IC - Instrument cluster	V	V	V	V	V																												
CLS-CLASS	218		Information	DVD player	V	V	V	V	V																												
CLS-CLASS	218		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
CLS-CLASS	218		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
CLS-CLASS	218		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
CLS-CLASS	218		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
CLS-CLASS	218		Information	CTEL/TEL - Cellular/Mobile telephone	V	V			V																												
CLS-CLASS	218		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
CLS-CLASS	218		Information	AUDIO/COMAND	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
CLS-CLASS	218		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
CLS-CLASS	218		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
CLS-CLASS	218		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
CLS-CLASS	218		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
CLS-CLASS	218		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																												
CLS-CLASS	218		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V		V																												
CLS-CLASS	218		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																												
CLS-CLASS	218		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
CLS-CLASS	218		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
CLS-CLASS	218		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
CLS-CLASS	218		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
CLS-CLASS	218		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
CLS-CLASS	218		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
CL-CLASS	215		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V																												
CL-CLASS	215		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
CL-CLASS	215		Drive	ESM - Electronic selector module	V	V	V	V	V																												
CL-CLASS	215		Drive	DTR - Distronic	V	V	V		V																												
CL-CLASS	215		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
CL-CLASS	215		Chassis	Suspension	V	V	V	V	V																												
CL-CLASS	215		Chassis	PSE - Pneumatic system equipment	V	V		V	V																												
CL-CLASS	215		Chassis	TPM - Tire pressure monitor	V	V			V																												
CL-CLASS	215		Body	UCP - Upper control panel	V	V	V	V	V																												
CL-CLASS	215		Body	System diagnosis	V	V			V																												
CL-CLASS	215		Body	SCM [MRM] - Steering column module	V	V		V	V																												
CL-CLASS	215		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V		V	V																												
CL-CLASS	215		Body	SAM-P- Passenger-side signal acquisition and actuation module	V	V		V	V																												
CL-CLASS	215		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V		V	V																												
CL-CLASS	215		Body	RCM - Rear control module	V	V		V	V																												
CL-CLASS	215		Body	OCP - Overhead control panel	V	V	V	V	V																												
CL-CLASS	215		Body	Multifunction control unit	V	V		V	V																												
CL-CLASS	215		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V	V	V																												
CL-CLASS	215		Body	HSW/LRH - Steering wheel heater	V	V		V	V																												
CL-CLASS	215		Body	Headlamp-R - Headlamp control unit	V	V	V		V																												
CL-CLASS	215		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
CL-CLASS	215		Body	EZS/EIS - Electronic ignition lock	V	V			V																												
CL-CLASS	215		Body	CGW - Central gateway	V	V			V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
CL-CLASS	215		Body	AHE - Trailer recognition	V	V		V	V																												
CL-CLASS	215		Body	AB - Airbag	V	V	V		V																												
CL-CLASS	215		Information	TV - TV tuner	V	V		V	V																												
CL-CLASS	215		Information	PTS - Parktronic system	V	V	V	V	V																												
CL-CLASS	215		Information	NAV - Navigation module	V	V			V																												
CL-CLASS	215		Information	IC - Instrument cluster	V	V	V	V	V																			V									
CL-CLASS	215		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V	V	V													V															
CL-CLASS	215		Information	AUDIO/COMAND	V	V		V	V																												
CL-CLASS	215		Information	AGW - Audio gateway	V	V		V	V																												
CL-CLASS	215		Seat/Door	OSB-FR - Multicontour backrest front right	V	V		V	V																												
CL-CLASS	215		Seat/Door	OSB-FL - Multicontour backrest front left	V	V		V	V																												
CL-CLASS	215		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V		V	V																												
CL-CLASS	215		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V		V	V																												
CL-CLASS	215		Seat/Door	DCM-FR - Door control module front right	V	V		V	V																												
CL-CLASS	215		Seat/Door	DCM-FL - Door control module front left	V	V		V	V																												
CL-CLASS	215		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
CL-CLASS	215		Air Conditioning	KBE-H/REAR AC - Rear air conditioning	V	V		V	V																												
CL-CLASS	215		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
CL-CLASS	216		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V					V						V							V						V
CL-CLASS	216		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
CL-CLASS	216		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
CL-CLASS	216		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
CL-CLASS	216		Drive	DTR - Distronic	V	V	V		V																												
CL-CLASS	216		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
CL-CLASS	216		Chassis	Suspension	V	V	V	V	V																												
CL-CLASS	216		Chassis	ES - Electrical power steering	V	V	V		V																												
CL-CLASS	216		Chassis	EFB - Electric parking brake	V	V	V	V	V																												
CL-CLASS	216		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
CL-CLASS	216		Body	WSS - Weight sensing system	V	V	V		V																												
CL-CLASS	216		Body	UCP - Upper control panel	V	V	V	V	V																												
CL-CLASS	216		Body	System diagnosis	V	V			V																												
CL-CLASS	216		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
CL-CLASS	216		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V		V																												
CL-CLASS	216		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V																												
CL-CLASS	216		Body	RCM - Rear control module	V	V	V	V	V																												
CL-CLASS	216		Body	OCP - Overhead control panel	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
CL-CLASS	216		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
CL-CLASS	216		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
CL-CLASS	216		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
CL-CLASS	216		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
CL-CLASS	216		Body	CGW - Central gateway	V	V			V																												
CL-CLASS	216		Body	BNS/BMS - Battery sensor	V	V	V	V	V																												
CL-CLASS	216		Body	AHE - Trailer recognition	V	V	V	V	V																												
CL-CLASS	216		Body	AB - Airbag	V	V	V		V																												
CL-CLASS	216		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
CL-CLASS	216		Information	VCS - Voice control	V	V	V		V																												
CL-CLASS	216		Information	TV - TV tuner	V	V	V		V																												
CL-CLASS	216		Information	Tuner - Standard tuner	V	V	V	V	V																												
CL-CLASS	216		Information	SGR - Radar sensors control unit	V	V	V	V	V																												
CL-CLASS	216		Information	MFK - Multifunction camera	V	V	V	V	V																												
CL-CLASS	216		Information	RFK - Backup camera	V	V	V		V																												
CL-CLASS	216		Information	PTS - Parktronic system	V	V	V	V	V																												
CL-CLASS	216		Information	NSA - Night View Assist	V	V	V	V	V																												
CL-CLASS	216		Information	NBR-LF - Left front range radar	V	V			V																												
CL-CLASS	216		Information	NAV - Navigation module	V	V	V	V	V																												
CL-CLASS	216		Information	MIF/UCI - Media interface	V	V	V		V																												
CL-CLASS	216		Information	ICI - InCar Internet	V	V	V		V																												
CL-CLASS	216		Information	IC - Instrument cluster	V	V	V	V	V																												
CL-CLASS	216		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
CL-CLASS	216		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
CL-CLASS	216		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
CL-CLASS	216		Information	AUDIO/COMAND	V	V	V	V	V																												
CL-CLASS	216		Information	ASSYST PLUS - PLUS Active Service System	V	V	V		V																												
CL-CLASS	216		Information	ASSYST Active Service System	V	V	V		V																										V		
CL-CLASS	216		Seat/Door	TLC/GTO - Garage door opener	V	V	V		V																												
CL-CLASS	216		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
CL-CLASS	216		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
CL-CLASS	216		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
CL-CLASS	216		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V		V																												
CL-CLASS	216		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V		V																												
CL-CLASS	216		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V		V																												
CL-CLASS	216		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
CL-CLASS	216		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
CL-CLASS	216		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
CL-CLASS	216		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
CL-CLASS	217		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
CL-CLASS	217		Drive	SG-EM - Power electronics	V	V			V																												
CL-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
CL-CLASS	217		Drive	DTR - Distronic	V	V			V																												
CL-CLASS	217		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
CL-CLASS	217		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
CL-CLASS	217		Drive	ETC - Electronic transmission control	V	V	V		V												V																
CL-CLASS	217		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
CL-CLASS	217		Chassis	TPM - Tire pressure monitor	V	V			V																												
CL-CLASS	217		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V							V																					
CL-CLASS	217		Chassis	ES - Electrical power steering	V	V	V		V																												
CL-CLASS	217		Chassis	Suspension	V	V			V																												
CL-CLASS	217		Chassis	EFB - Electric parking brake	V	V	V	V	V																												
CL-CLASS	217		Information	TPAD - Touchpad	V	V	V	V	V																												
CL-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio	V	V			V																												
CL-CLASS	217		Information	360' - Camera	V	V	V	V	V																												
CL-CLASS	217		Information	SOUND - Sound system	V	V			V																												
CL-CLASS	217		Information	RFK - Backup camera	V	V	V	V	V																												
CL-CLASS	217		Information	SGR - Radar sensors control unit	V	V	V		V																												
CL-CLASS	217		Information	PTS - Parktronic system	V	V	V	V	V																												
CL-CLASS	217		Information	NSA - Night View Assist	V	V			V																												
CL-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
CL-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
CL-CLASS	217		Information	NBR-RF - Right front range radar					V																												
CL-CLASS	217		Information	NBR-LF - Left front range radar					V																												
CL-CLASS	217		Information	MFK - Multifunction camera	V	V	V	V	V																												
CL-CLASS	217		Information	Head-up display	V	V		V	V																												
CL-CLASS	217		Information	AUDIO/COMAND	V	V			V																												
CL-CLASS	217		Information	ZAN - Audio/COMAND display	V	V			V																												
CL-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
CL-CLASS	217		Information	KAB - Camera cover	V	V	V	V	V																												
CL-CLASS	217		Information	IC - Instrument cluster	V	V	V	V	V																												
CL-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
CL-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V			V																												
CL-CLASS	217		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
CL-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
CL-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
CL-CLASS	217		Body	AB - Airbag	V	V			V																												
CL-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
CL-CLASS	217		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
CL-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V														V														
CL-CLASS	217		Body	SG-AWF - Collision prevention assist	V	V			V																												
CL-CLASS	217		Body	EZS/EIS - Electronic ignition lock	V	V			V																												
CL-CLASS	217		Body	BNS/BMS - Battery sensor	V	V	V		V																												
CL-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
CL-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
CL-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
CL-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
CL-CLASS	217		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
CL-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V			V																												
CL-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V			V																												
CL-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V			V																												
CL-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control	V	V			V																												
CL-CLASS	217		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
CL-CLASS	217		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
CL-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control	V	V			V																												
CL-CLASS	217		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
SLK-CLASS	170		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V																								
SLK-CLASS	170		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
SLK-CLASS	170		Drive	ESM - Electronic selector module	V	V	V	V	V																												
SLK-CLASS	170		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
SLK-CLASS	170		Chassis	VP - Vacuum pump brake booster	V	V	V	V	V																												
SLK-CLASS	170		Chassis	BAS - Brake assist	V	V	V		V																												
SLK-CLASS	170		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V	V	V																												
SLK-CLASS	170		Body	AB - Airbag	V		V		V																												
SLK-CLASS	170		Information	IC - Instrument cluster	V	V	V	V	V																			V									
SLK-CLASS	170		Information	DTA - Mbrace or TELEAID/GPS Box	V	V		V	V													V															
SLK-CLASS	170		Information	AUDIO/COMAND	V	V		V	V																												
SLK-CLASS	170		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
SLK-CLASS	170		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
SLK-CLASS	171		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V											V							V						
SLK-CLASS	171		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
SLK-CLASS	171		Drive	ESM - Electronic selector module	V	V	V	V	V																												
SLK-CLASS	171		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
SLK-CLASS	171		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
SLK-CLASS	171		Body	WSS - Weight sensing system	V	V	V		V																												
SLK-CLASS	171		Body	UCP - Upper control panel	V	V	V	V	V																												
SLK-CLASS	171		Body	System diagnosis	V	V			V																												
SLK-CLASS	171		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
SLK-CLASS	171		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
SLK-CLASS	171		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V																												
SLK-CLASS	171		Body	OCP - Overhead control panel	V	V	V	V	V																												
SLK-CLASS	171		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
SLK-CLASS	171		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
SLK-CLASS	171		Body	CGW - Central gateway	V	V			V																												
SLK-CLASS	171		Body	AB - Airbag	V	V	V		V																												
SLK-CLASS	171		Information	TV - TV tuner	V	V			V																												
SLK-CLASS	171		Information	SOUND - Sound system	V	V	V	V	V																												
SLK-CLASS	171		Information	PTS - Parktronic system	V	V	V	V	V																												
SLK-CLASS	171		Information	MIF/UCI - Media interface	V	V	V		V																												
SLK-CLASS	171		Information	IC - Instrument cluster	V	V	V	V	V																												
SLK-CLASS	171		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
SLK-CLASS	171		Information	DAB/SDAR - Digital/Satellite radio	V	V	V		V																												
SLK-CLASS	171		Information	CTEL/TEL - Cellular/Mobile telephone	V	V	V		V																												
SLK-CLASS	171		Information	AUDIO/COMAND	V	V	V	V	V																												
SLK-CLASS	171		Information	ASSYST PLUS - PLUS Active Service System	V	V	V		V																												
SLK-CLASS	171		Information	ASSYST Active Service System	V	V	V		V																										V		
SLK-CLASS	171		Information	AGW - Audio gateway	V	V	V	V	V																												
SLK-CLASS	171		Seat/Door	RVC/VDS - Convertible roof control	V	V	V	V	V																												
SLK-CLASS	171		Seat/Door	HS - Seat heater	V	V	V	V	V																												
SLK-CLASS	171		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
SLK-CLASS	171		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
SLK-CLASS	171		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
SLK-CLASS	171		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
SLK-CLASS	171		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
SLK-CLASS	172		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
SLK-CLASS	172		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
SLK-CLASS	172		Drive	ESM - Electronic selector module	V	V	V	V	V																												
SLK-CLASS	172		Drive	DTR - Distronic	V	V	V		V																												
SLK-CLASS	172		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
SLK-CLASS	172		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
SLK-CLASS	172		Chassis	Suspension	V	V	V	V	V																												
SLK-CLASS	172		Chassis	ES - Electrical power steering	V	V	V		V																												
SLK-CLASS	172		Chassis	EFB - Electric parking brake	V	V	V		V																												
SLK-CLASS	172		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
SLK-CLASS	172		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
SLK-CLASS	172		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
SLK-CLASS	172		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
SLK-CLASS	172		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
SLK-CLASS	172		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
SLK-CLASS	172		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
SLK-CLASS	172		Body	HS/AIRSCARF - Seat heater/Air scarf system	V	V	V	V	V																												
SLK-CLASS	172		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
SLK-CLASS	172		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
SLK-CLASS	172		Body	CGW - Central gateway	V	V	V		V																												
SLK-CLASS	172		Body	AB - Airbag	V	V	V		V																												
SLK-CLASS	172		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
SLK-CLASS	172		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
SLK-CLASS	172		Information	TV - TV tuner	V	V	V		V																												
SLK-CLASS	172		Information	SOUND - Sound system	V	V	V	V	V																												
SLK-CLASS	172		Information	SGR - Radar sensors control unit	V	V	V		V																												
SLK-CLASS	172		Information	MFK - Multifunction camera	V	V	V	V	V																												
SLK-CLASS	172		Information	PTS - Parktronic system	V	V	V	V	V																												
SLK-CLASS	172		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
SLK-CLASS	172		Information	NBR-RF - Right front range radar	V	V			V																												
SLK-CLASS	172		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
SLK-CLASS	172		Information	NBR-LF - Left front range radar	V	V			V																												
SLK-CLASS	172		Information	NAV - Navigation module	V	V	V	V	V																												
SLK-CLASS	172		Information	MIF/UCI - Media interface	V	V	V		V																												
SLK-CLASS	172		Information	IC - Instrument cluster	V	V	V	V	V																												
SLK-CLASS	172		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
SLK-CLASS	172		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
SLK-CLASS	172		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
SLK-CLASS	172		Information	AUDIO/COMAND	V	V	V	V	V																												
SLK-CLASS	172		Seat/Door	RVC/VDS - Convertible roof control	V	V	V	V	V																												
SLK-CLASS	172		Seat/Door	PSD/MSC - Sliding roof control	V	V	V		V																												
SLK-CLASS	172		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
SLK-CLASS	172		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
SLK-CLASS	172		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
SLK-CLASS	172		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
SLK-CLASS	172		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
SL-CLASS	129		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V																												
SL-CLASS	129		Drive	ETC - Electronic transmission control	V		V	V	V																												
SL-CLASS	129		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
SL-CLASS	129		Chassis	BAS - Brake assist	V	V			V																												
SL-CLASS	129		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V	V	V																												
SL-CLASS	129		Body	AB - Airbag	V		V		V																												
SL-CLASS	129		Information	NAV - Navigation module	V	V			V																												
SL-CLASS	129		Information	IC - Instrument cluster	V	V	V	V	V																		V										
SL-CLASS	129		Information	DTA - Mbrace or TELEAID/GPS Box	V	V		V	V												V																
SL-CLASS	129		Information	AUDIO/COMAND	V	V		V	V																												
SL-CLASS	129		Information	APS - Auto pilot system	V	V			V																												
SL-CLASS	129		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
SL-CLASS	129		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
SL-CLASS	230		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V										V							V							
SL-CLASS	230		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
SL-CLASS	230		Drive	ESM - Electronic selector module	V	V	V	V	V																												
SL-CLASS	230		Drive	DTR - Distronic	V	V	V		V																												
SL-CLASS	230		Drive	AMG DRIVE UNIT	V	V	V	V	V																												
SL-CLASS	230		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
SL-CLASS	230		Chassis	Suspension	V	V	V	V	V																												
SL-CLASS	230		Chassis	SBC - Sensotronic Brake Control	V	V	V		V							V																					
SL-CLASS	230		Chassis	PSE - Pneumatic system equipment	V	V		V	V																												
SL-CLASS	230		Chassis	HS/AIRSCARF - Seat heater/Air scarf system	V	V	V	V	V																												
SL-CLASS	230		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
SL-CLASS	230		Body	WSS - Weight sensing system	V	V	V		V																												
SL-CLASS	230		Body	System diagnosis	V	V			V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
SL-CLASS	230		Body	SCM [MRM] - Steering column module	V	V		V	V																												
SL-CLASS	230		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V		V	V																												
SL-CLASS	230		Body	SAM-P- Passenger-side signal acquisition and actuation module	V	V		V	V																												
SL-CLASS	230		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V		V	V																												
SL-CLASS	230		Body	OCP - Overhead control panel	V	V		V	V																												
SL-CLASS	230		Body	LCP/HBF - Lower/Rear control panel	V	V		V	V																												
SL-CLASS	230		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V	V	V																												
SL-CLASS	230		Body	HSW/LRH - Steering wheel heater	V	V		V	V																												
SL-CLASS	230		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
SL-CLASS	230		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
SL-CLASS	230		Body	EZS/EIS - Electronic ignition lock	V	V			V																												
SL-CLASS	230		Body	CGW - Central gateway	V	V			V																												
SL-CLASS	230		Body	BNS/BMS - Battery sensor	V	V			V																												
SL-CLASS	230		Body	AB - Airbag	V	V	V		V																												
SL-CLASS	230		Information	TV - TV tuner	V	V		V	V																												
SL-CLASS	230		Information	SOUND - Sound system	V	V	V	V	V																												
SL-CLASS	230		Information	PTS - Parktronic system	V	V	V	V	V																												
SL-CLASS	230		Information	MIF/UCI - Media interface	V	V	V		V																												
SL-CLASS	230		Information	IC - Instrument cluster	V	V	V	V	V																												
SL-CLASS	230		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V	V	V													V															
SL-CLASS	230		Information	DAB/SDAR - Digital/Satellite radio	V	V	V		V																												
SL-CLASS	230		Information	CTEL/TEL - Cellular/Mobile telephone	V	V	V		V																												
SL-CLASS	230		Information	AUDIO/COMAND	V	V	V	V	V																												
SL-CLASS	230		Information	AGW - Audio gateway	V	V		V	V																												
SL-CLASS	230		Seat/Door	RVC/VDS - Convertible roof control	V	V	V	V	V																												
SL-CLASS	230		Seat/Door	OSB-FR - Multicontour backrest front right	V	V		V	V																												
SL-CLASS	230		Seat/Door	OSB-FL - Multicontour backrest front left	V	V		V	V																												
SL-CLASS	230		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V		V	V																												
SL-CLASS	230		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V		V	V																												
SL-CLASS	230		Seat/Door	DCM-FR - Door control module front right	V	V		V	V																												
SL-CLASS	230		Seat/Door	DCM-FL - Door control module front left	V	V		V	V																												
SL-CLASS	230		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V		V	V																												
SL-CLASS	230		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
SL-CLASS	231		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V				V					V						V													V
SL-CLASS	231		Drive	ETC - Electronic transmission control	V	V	V		V												V																
SL-CLASS	231		Drive	ISM - Intelligent servo module	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
SL-CLASS	231		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
SL-CLASS	231		Drive	DTR - Distronic	V	V	V		V																												
SL-CLASS	231		Drive	DSI - Direct select interface	V	V	V	V	V																												
SL-CLASS	231		Drive	AMG DRIVE UNIT	V	V	V	V	V																												
SL-CLASS	231		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
SL-CLASS	231		Chassis	Suspension	V	V	V	V	V																												
SL-CLASS	231		Chassis	ES - Electrical power steering	V	V	V		V																												
SL-CLASS	231		Chassis	EFB - Electric parking brake	V	V	V		V																												
SL-CLASS	231		Chassis	FWGW - Chassis gateway	V	V	V		V																												
SL-CLASS	231		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
SL-CLASS	231		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
SL-CLASS	231		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
SL-CLASS	231		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
SL-CLASS	231		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
SL-CLASS	231		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
SL-CLASS	231		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
SL-CLASS	231		Body	HS/AIRSCARF - Seat heater/Air scarf system	V	V	V	V	V																												
SL-CLASS	231		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
SL-CLASS	231		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
SL-CLASS	231		Body	CGW - Central gateway	V	V	V		V																												
SL-CLASS	231		Body	AB - Airbag	V	V	V		V																												
SL-CLASS	231		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
SL-CLASS	231		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
SL-CLASS	231		Information	TV - TV tuner	V	V	V		V																												
SL-CLASS	231		Information	SOUND - Sound system	V	V	V	V	V																												
SL-CLASS	231		Information	SGR - Radar sensors control unit	V	V	V		V																												
SL-CLASS	231		Information	RFK - Backup camera	V	V	V	V	V																												
SL-CLASS	231		Information	MFK - Multifunction camera	V	V	V	V	V																												
SL-CLASS	231		Information	PTS - Parktronic system	V	V	V	V	V																												
SL-CLASS	231		Information	NSA - Night View Assist	V	V	V		V																												
SL-CLASS	231		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
SL-CLASS	231		Information	NBR-RF - Right front range radar	V	V			V																												
SL-CLASS	231		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
SL-CLASS	231		Information	NBR-LF - Left front range radar	V	V			V																												
SL-CLASS	231		Information	MIF/UCI - Media interface	V	V	V		V																												
SL-CLASS	231		Information	IC - Instrument cluster	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
SL-CLASS	231		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
SL-CLASS	231		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
SL-CLASS	231		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
SL-CLASS	231		Information	AUDIO/COMAND	V	V	V	V	V																												
SL-CLASS	231		Information	AMG Performance Media	V	V	V		V																												
SL-CLASS	231		Seat/Door	RVC/VDS - Convertible roof control	V	V	V	V	V																												
SL-CLASS	231		Seat/Door	PSD/MSC - Sliding roof control	V	V	V		V																												
SL-CLASS	231		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
SL-CLASS	231		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
SL-CLASS	231		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																												
SL-CLASS	231		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V		V																												
SL-CLASS	231		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																												
SL-CLASS	231		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
SL-CLASS	231		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
SL-CLASS	231		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
SLS-CLASS	197		Drive	PTCU - Common powertrain controller	V	V	V		V																												
SLS-CLASS	197		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V										V							V							
SLS-CLASS	197		Drive	ETC - Electronic transmission control	V	V	V		V												V																
SLS-CLASS	197		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
SLS-CLASS	197		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
SLS-CLASS	197		Drive	DSI - Direct select interface	V	V	V	V	V																												
SLS-CLASS	197		Drive	AMG DRIVE UNIT	V	V	V	V	V																												
SLS-CLASS	197		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
SLS-CLASS	197		Chassis	Suspension	V	V	V	V	V																												
SLS-CLASS	197		Chassis	ES - Electrical power steering	V	V	V		V																												
SLS-CLASS	197		Chassis	EFB - Electric parking brake	V	V	V	V	V																												
SLS-CLASS	197		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
SLS-CLASS	197		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
SLS-CLASS	197		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
SLS-CLASS	197		Body	CSHV - Crash sensor/high-voltage battery	V	V			V																												
SLS-CLASS	197		Body	BNS/BMS - Battery sensor	V	V	V	V	V				V					V					V														V
SLS-CLASS	197		Body	WSS - Weight sensing system	V	V	V		V																												
SLS-CLASS	197		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
SLS-CLASS	197		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
SLS-CLASS	197		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
SLS-CLASS	197		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
SLS-CLASS	197		Body	HS/AIRSCARF - Seat heater/Air scarf system	V	V	V	V	V																												
SLS-CLASS	197		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
SLS-CLASS	197		Body	CGW - Central gateway	V	V	V		V																												
SLS-CLASS	197		Body	AB - Airbag	V	V	V		V																												
SLS-CLASS	197		Information	MFK - Multifunction camera	V	V	V	V	V																												
SLS-CLASS	197		Information	SGR - Radar sensors control unit	V	V	V		V																												
SLS-CLASS	197		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
SLS-CLASS	197		Information	SOUND - Sound system	V	V	V	V	V																												
SLS-CLASS	197		Information	PTS - Parktronic system	V	V	V	V	V																												
SLS-CLASS	197		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
SLS-CLASS	197		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
SLS-CLASS	197		Information	MIF/UCI - Media interface	V	V	V		V																												
SLS-CLASS	197		Information	IC - Instrument cluster	V	V	V	V	V																												
SLS-CLASS	197		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
SLS-CLASS	197		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
SLS-CLASS	197		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
SLS-CLASS	197		Information	AUDIO/COMAND	V	V	V	V	V																												
SLS-CLASS	197		Information	AMG Performance Media	V	V	V		V																												
SLS-CLASS	197		Seat/Door	RVC/VDS - Convertible roof control	V	V	V	V	V																												
SLS-CLASS	197		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
SLS-CLASS	197		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
SLS-CLASS	197		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
SLS-CLASS	197		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
SLS-CLASS	197		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
AMG GT	190		Drive	DTR - Distronic	V	V	V		V																												
AMG GT	190		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																												
AMG GT	190		Drive	DSI - Direct select interface	V	V	V	V	V																												
AMG GT	190		Drive	AMG DRIVE UNIT	V	V	V	V	V																												
AMG GT	190		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
AMG GT	190		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V			V				V					V															V
AMG GT	190		Drive	ETC - Electronic transmission control	V	V	V		V										V																		
AMG GT	190		Chassis	TPM - Tire pressure monitor	V	V			V																												
AMG GT	190		Chassis	Suspension	V	V	V	V	V																												
AMG GT	190		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
AMG GT	190		Chassis	EFB - Electric parking brake	V	V	V		V																												
AMG GT	190		Information	TPAD - Touchpad	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
AMG GT	190		Information	DAB/SDAR - Digital/Satellite radio	V	V			V																												
AMG GT	190		Information	SOUND - Sound system	V	V			V																												
AMG GT	190		Information	RFK - Backup camera	V	V	V	V	V																												
AMG GT	190		Information	PTS - Parktronic system	V	V	V	V	V																												
AMG GT	190		Information	MFK - Multifunction camera	V	V	V	V	V																												
AMG GT	190		Information	IC - Instrument cluster	V	V	V	V	V																												
AMG GT	190		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
AMG GT	190		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V			V																												
AMG GT	190		Information	AUDIO/COMAND	V	V			V																												
AMG GT	190		Information	ZAN - Audio/COMAND display	V	V			V																												
AMG GT	190		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
AMG GT	190		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
AMG GT	190		Information	AMG Performance Media	V	V	V		V																												
AMG GT	190		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
AMG GT	190		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
AMG GT	190		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
AMG GT	190		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V		V																												
AMG GT	190		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V		V																												
AMG GT	190		Body	AB - Airbag	V	V	V		V																												
AMG GT	190		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V		V																												
AMG GT	190		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
AMG GT	190		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
AMG GT	190		Body	SG-AWF - Collision prevention assist	V	V	V		V																												
AMG GT	190		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
AMG GT	190		Body	CGW - Central gateway	V	V	V		V																												
AMG GT	190		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
AMG GT	190		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
AMG GT	190		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
AMG GT	190		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
AMG GT	190		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											
SLR-CLASS	199		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V																												
SLR-CLASS	199		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
SLR-CLASS	199		Drive	ESM - Electronic selector module	V	V	V	V	V																												
SLR-CLASS	199		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
SLR-CLASS	199		Chassis	SBC - Sensotronic Brake Control	V	V	V		V								V																				
SLR-CLASS	199		Chassis	TPM - Tire pressure monitor	V	V	V		V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
SLR-CLASS	199		Body	WSS - Weight sensing system	V	V	V		V																												
SLR-CLASS	199		Body	SCM [MRM] - Steering column module	V	V		V	V																												
SLR-CLASS	199		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V		V	V																												
SLR-CLASS	199		Body	SAM-P- Passenger-side signal acquisition and actuation module	V	V		V	V																												
SLR-CLASS	199		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V		V	V																												
SLR-CLASS	199		Body	OCP - Overhead control panel	V	V		V	V																												
SLR-CLASS	199		Body	LCP/HBF - Lower/Rear control panel	V	V		V	V																												
SLR-CLASS	199		Body	Headlamp-R - Headlamp control unit	V	V	V		V																												
SLR-CLASS	199		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
SLR-CLASS	199		Body	EZS/EIS - Electronic ignition lock	V	V			V																												
SLR-CLASS	199		Body	CGW - Central gateway	V	V			V																												
SLR-CLASS	199		Body	BNS/BMS - Battery sensor	V	V			V																												
SLR-CLASS	199		Body	AB - Airbag	V	V	V		V																												
SLR-CLASS	199		Information	IC - Instrument cluster	V	V	V	V	V																												
SLR-CLASS	199		Information	DTA - Mbrace or TELEAID/GPS Box	V	V		V	V													V															
SLR-CLASS	199		Information	AUDIO/COMAND	V	V		V	V																												
SLR-CLASS	199		Seat/Door	DCM-FR - Door control module front right	V	V		V	V																												
SLR-CLASS	199		Seat/Door	DCM-FL - Door control module front left	V	V		V	V																												
SLR-CLASS	199		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V																												
MAYBACH	240		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V											V						V							
MAYBACH	240		Drive	ETC - Electronic transmission control	V	V	V	V	V																												
MAYBACH	240		Drive	ESM - Electronic selector module	V	V	V	V	V																												
MAYBACH	240		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V		V																								V				
MAYBACH	240		Drive	DTR - Distronic	V	V	V		V																												
MAYBACH	240		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V																												
MAYBACH	240		Chassis	Suspension	V	V	V	V	V																												
MAYBACH	240		Chassis	SBC - Sensotronic Brake Control	V	V	V		V								V																				
MAYBACH	240		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
MAYBACH	240		Body	WSS - Weight sensing system	V	V	V		V																												
MAYBACH	240		Body	System diagnosis	V	V			V																												
MAYBACH	240		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
MAYBACH	240		Body	HSW/LRH - Steering wheel heater	V	V	V	V	V																												
MAYBACH	240		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V																												
MAYBACH	240		Body	AB - Airbag	V	V	V		V																												
MAYBACH	240		Information	TV - TV tuner	V	V			V																												
MAYBACH	240		Information	PTS - Parktronic system	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
MAYBACH	240		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V		V																												
MAYBACH	240		Information	AGW - Audio gateway	V	V	V	V	V																												
MAYBACH	240		Seat/Door	REDC/RWT - Rear end door control module	V	V	V	V	V																												
MAYBACH	240		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Drive	SG-EM - Power electronics	V	V			V																												
All_Model(BETA)	16P Connector		Drive	HFPM - Haptic accelerator pedal module	V	V			V																												
All_Model(BETA)	16P Connector		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V	V		V		V					V		V				V		V					V						V
All_Model(BETA)	16P Connector		Drive	ETC - Electronic transmission control	V	V	V	V	V												V																
All_Model(BETA)	16P Connector		Drive	ESM - Electronic selector module	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Drive	VG - Transfer case	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Drive	VECU - Power monitoring control unit	V	V			V																												
All_Model(BETA)	16P Connector		Drive	SG-EM-B - Electric motor control unit B	V	V	V		V																												
All_Model(BETA)	16P Connector		Drive	SG-EM-A - Electric motor control unit A	V	V	V		V																												
All_Model(BETA)	16P Connector		Drive	SCR - Selective catalytic reduction	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Drive	PTCU - Common powertrain controller	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Drive	Natural gas control unit	V	V			V																												
All_Model(BETA)	16P Connector		Drive	ISM - Intelligent servo module	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Drive	Hydrogen tank control unit	V	V			V																												
All_Model(BETA)	16P Connector		Drive	HSG - Hybrid control unit	V	V	V	V	V						V																						
All_Model(BETA)	16P Connector		Drive	High-temperature coolant pump control unit	V	V			V																												
All_Model(BETA)	16P Connector		Drive	Fuel cell control unit	V	V			V																												
All_Model(BETA)	16P Connector		Drive	FSCU-R - Control unit fuel pump	V	V	V		V																												
All_Model(BETA)	16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump	V	V	V	V	V																								V				
All_Model(BETA)	16P Connector		Drive	EMPI - Electronic Motor Pump Inverter	V	V			V																												
All_Model(BETA)	16P Connector		Drive	Electric drive control unit	V	V			V																												
All_Model(BETA)	16P Connector		Drive	DTR - Distronic	V	V	V		V																												
All_Model(BETA)	16P Connector		Drive	DSI - Direct select interface	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Drive	Compressed Natural Gas Control Module	V	V			V																												
All_Model(BETA)	16P Connector		Drive	CC - Cruise control	V		V		V																												
All_Model(BETA)	16P Connector		Drive	BSA - Belt-driven starter/alternator	V	V			V																												
All_Model(BETA)	16P Connector		Drive	AMG DRIVE UNIT	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Drive	ACS - Automatic clutch system	V	V			V																												
All_Model(BETA)	16P Connector		Chassis	ABS/ESP - Electronic stability program	V	V	V	V	V					V	V																						
All_Model(BETA)	16P Connector		Chassis	Suspension	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Chassis	SBC - Sensotronic Brake Control	V	V	V		V								V																				
All_Model(BETA)	16P Connector		Chassis	PSE - Pneumatic system equipment	V	V		V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
All_Model(BETA)	16P Connector		Chassis	HS/AIRSCARF - Seat heater/Air scarf system	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Chassis	HAQ - Interwheel differential lock at rear axle	V	V	V		V																												
All_Model(BETA)	16P Connector		Chassis	FWGW - Chassis gateway	V	V	V		V																												
All_Model(BETA)	16P Connector		Chassis	ES - Electrical power steering	V	V	V		V																												
All_Model(BETA)	16P Connector		Chassis	EFB - Electric parking brake	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Chassis	BAS - Brake assist	V	V	V		V																												
All_Model(BETA)	16P Connector		Chassis	VP - Vacuum pump brake booster	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Chassis	TPM - Tire pressure monitor	V	V	V		V																												
All_Model(BETA)	16P Connector		Body	SG-LML-VR - LED matrix of right front lamp unit	V	V			V																												
All_Model(BETA)	16P Connector		Body	SG-LML-VL - LED matrix of left front lamp unit	V	V			V																												
All_Model(BETA)	16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system	V	V			V																												
All_Model(BETA)	16P Connector		Body	CSHV - Crash sensor/high-voltage battery	V	V			V																												
All_Model(BETA)	16P Connector		Body	WSS - Weight sensing system	V	V	V		V																												
All_Model(BETA)	16P Connector		Body	UCP - Upper control panel	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	System diagnosis	V	V			V																												
All_Model(BETA)	16P Connector		Body	SG-DDW - DC/DC converter control unit	V	V	V		V																												
All_Model(BETA)	16P Connector		Body	SG-AWF - Collision prevention assist	V	V	V		V																												
All_Model(BETA)	16P Connector		Body	SCM [MRM] - Steering column module	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	SAM-P- Passenger-side signal acquisition and actuation module	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side	V	V	V	V	V			V																									
All_Model(BETA)	16P Connector		Body	RevETR-RF - Right front reversible emergency tensioning retractor	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	RevETR-LF - Left front reversible emergency tensioning retractor	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	RCM - Rear control module	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	OCP - Overhead control panel	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	Multifunction control unit	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	LCP/HBF - Lower/Rear control panel	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	LAE [LAA] - Loading floor automatically extendable	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	HSW/LRH - Steering wheel heater	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	Headlamp-R - Headlamp control unit	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit	V	V	V	V	V														V														
All_Model(BETA)	16P Connector		Body	EZS/EIS - Electronic ignition lock	V	V	V		V																												
All_Model(BETA)	16P Connector		Body	CGW - Central gateway	V	V	V		V																												
All_Model(BETA)	16P Connector		Body	BNS/BMS - Battery sensor	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
All_Model(BETA)	16P Connector		Body	AHE - Trailer recognition	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Body	AB - Airbag	V	V	V		V																												
All_Model(BETA)	16P Connector		Body	AAM - All activity module	V				V																												
All_Model(BETA)	16P Connector		Information	TPAD - Touchpad	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	Head-up display	V	V		V	V																												
All_Model(BETA)	16P Connector		Information	Drive Kit Plus - Drive kit for iPhone(R)	V	V			V																												
All_Model(BETA)	16P Connector		Information	KAB - Camera cover	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	ZAN - Audio/COMAND display	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	VCS - Voice control	V	V	V		V																												
All_Model(BETA)	16P Connector		Information	TV - TV tuner	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	Tuner - Standard tuner	V	V	V		V																												
All_Model(BETA)	16P Connector		Information	Sound generator for exhaust system	V	V	V		V																												
All_Model(BETA)	16P Connector		Information	SOUND - Sound system	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	SGR - Radar sensors control unit	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	360' - Camera	V	V	V		V																												
All_Model(BETA)	16P Connector		Information	MFK - Multifunction camera	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	RFK - Backup camera	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	PTS - Parktronic system	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	NSA - Night View Assist	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar	V	V	V		V																												
All_Model(BETA)	16P Connector		Information	NBR-RF - Right front range radar	V	V			V																												
All_Model(BETA)	16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar	V	V			V																												
All_Model(BETA)	16P Connector		Information	NBR-LF - Left front range radar	V	V			V																												
All_Model(BETA)	16P Connector		Information	NAV - Navigation module	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	MIF/UCI - Media interface	V	V	V		V																												
All_Model(BETA)	16P Connector		Information	ICI - InCar Internet	V	V	V		V																												
All_Model(BETA)	16P Connector		Information	IC - Instrument cluster	V	V	V	V	V																		V										
All_Model(BETA)	16P Connector		Information	DVD player	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box	V	V	V	V	V													V															
All_Model(BETA)	16P Connector		Information	D-FOR - Display in right rear passenger	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	D-FOL - Display in left rear passenger	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	DAB/SDAR - Digital/Satellite radio	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone	V	V	V		V																												
All_Model(BETA)	16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit	V	V	V	V	V																												
All_Model(BETA)	16P Connector		Information	CM - Compass module	V	V	V		V																												
All_Model(BETA)	16P Connector		Information	AVE-H - Rear audio video unit	V	V	V	V	V																												

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function 'Tire pressure loss warning'	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)
All Model(BETA)	16P Connector		Information	AUDIO/COMAND	V	V	V	V	V																												
All Model(BETA)	16P Connector		Information	ASSYST PLUS - PLUS Active Service System	V	V	V		V																												
All Model(BETA)	16P Connector		Information	ASSYST Active Service System	V	V	V		V																									V			
All Model(BETA)	16P Connector		Information	APS - Auto pilot system	V	V			V																												
All Model(BETA)	16P Connector		Information	AMG Performance Media	V	V	V		V																												
All Model(BETA)	16P Connector		Information	AGW - Audio gateway	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	Right rear ESE - Right electrical seat adjustment	V	V			V																												
All Model(BETA)	16P Connector		Seat/Door	Left rear ESE - Left electrical seat adjustment	V	V			V																												
All Model(BETA)	16P Connector		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat	V	V			V																												
All Model(BETA)	16P Connector		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat	V	V			V																												
All Model(BETA)	16P Connector		Seat/Door	TSG-MR - Right center door control unit	V	V	V		V																												
All Model(BETA)	16P Connector		Seat/Door	TSG-ML - Left center door control unit	V	V	V		V																												
All Model(BETA)	16P Connector		Seat/Door	TLC/GTO - Garage door opener	V	V	V		V																												
All Model(BETA)	16P Connector		Seat/Door	RVC/VDS - Convertible roof control	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	REDC/RWT - Rear end door control module	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	PSD/MSC - Sliding roof control	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	OSB-R - Multicontour backrest rear	V	V		V	V																												
All Model(BETA)	16P Connector		Seat/Door	OSB-FR - Multicontour backrest front right	V	V		V	V																												
All Model(BETA)	16P Connector		Seat/Door	OSB-FL - Multicontour backrest front left	V	V		V	V																												
All Model(BETA)	16P Connector		Seat/Door	MKL-HR - Rear right multicontour backrest	V	V	V		V																												
All Model(BETA)	16P Connector		Seat/Door	MKL-HL - Rear left multicontour backrest	V	V	V		V																												
All Model(BETA)	16P Connector		Seat/Door	HS - Seat heater	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	HKS - Tailgate control	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	ESA-R - Electric seat adjustment rear	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	ERA - Electric fold down backrest system	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat	V	V	V	V	V																			V									
All Model(BETA)	16P Connector		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat	V	V	V	V	V																			V									
All Model(BETA)	16P Connector		Seat/Door	DCM-RR - Door control module rear right	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	DCM-RL - Door control module rear left	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	DCM-FR - Door control module front right	V	V	V	V	V																												
All Model(BETA)	16P Connector		Seat/Door	DCM-FL - Door control module front left	V	V	V	V	V																												
All Model(BETA)	16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control	V	V	V	V	V																												
All Model(BETA)	16P Connector		Air Conditioning	KBE-H/REAR AC - Rear air conditioning	V	V	V	V	V																												
All Model(BETA)	16P Connector		Air Conditioning	HBF - Rear control panel	V	V	V	V	V																												
All Model(BETA)	16P Connector		Air Conditioning	HB - Heater booster	V	V	V	V	V																												
All Model(BETA)	16P Connector		Air Conditioning	EKMK - Electric refrigerant compressor	V	V	V		V																												
All Model(BETA)	16P Connector		Air Conditioning	AAC - Automatic air conditioning	V	V	V	V	V	V																											

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
A-CLASS	68		Drive	ME/CDI/CNG - Engine control unit																																		
A-CLASS	68		Drive	ETC - Electronic transmission control																																		
A-CLASS	68		Drive	ESM - Electronic selector module																																		
A-CLASS	68		Drive	ACS - Automatic clutch system																																		
A-CLASS	68		Chassis	ABS/ESP - Electronic stability program																																		
A-CLASS	168		Chassis	ABS/ESP - Electronic stability program																																		
A-CLASS	168		Body	LCP/HBF - Lower/Rear control panel																																		
A-CLASS	168		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																		
A-CLASS	168		Body	ATA - ATA [EDW]/tow-away/interior protection																																		
A-CLASS	168		Body	AB - Airbag																																		
A-CLASS	168		Information	PTS - Parktronic system																																		
A-CLASS	168		Information	IC - Instrument cluster																																		
A-CLASS	168		Information	AUDIO/COMAND																																		
A-CLASS	168		Information	APS - Auto pilot system																																		
A-CLASS	168		Seat/Door	DCM-RR - Door control module rear right																																		
A-CLASS	168		Seat/Door	DCM-RL - Door control module rear left																																		
A-CLASS	168		Seat/Door	DCM-FR - Door control module front right																																		
A-CLASS	168		Seat/Door	DCM-FL - Door control module front left																																		
A-CLASS	168		Air Conditioning	TSTH/STH - Stationary heater with remote control																					V													
A-CLASS	168		Air Conditioning	HB - Heater booster																					V													
A-CLASS	168		Air Conditioning	AAC - Automatic air conditioning																																		
A-CLASS	169		Drive	ME/CDI/CNG - Engine control unit				V																									V					
A-CLASS	169		Drive	ETC - Electronic transmission control																																		
A-CLASS	169		Drive	ESM - Electronic selector module																																		
A-CLASS	169		Drive	BSA - Belt-driven starter/alternator																																		
A-CLASS	169		Chassis	ABS/ESP - Electronic stability program			V																						V									
A-CLASS	169		Chassis	ES - Electrical power steering																																		
A-CLASS	169		Body	SCM [MRM] - Steering column module																																		
A-CLASS	169		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																		
A-CLASS	169		Body	OCP - Overhead control panel																																		
A-CLASS	169		Body	Multifunction control unit																																		
A-CLASS	169		Body	Headlamp-R - Headlamp control unit																																		
A-CLASS	169		Body	Headlamp/Headlamp-L - Headlamp control unit																																		
A-CLASS	169		Body	EZS/EIS - Electronic ignition lock																																		
A-CLASS	169		Body	CGW - Central gateway																																		
A-CLASS	169		Body	ATA - ATA [EDW]/tow-away/interior protection																																		

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
A-CLASS	169		Body	AHE - Trailer recognition																																	
A-CLASS	169		Body	AB - Airbag																																	
A-CLASS	169		Information	SOUND - Sound system																																	
A-CLASS	169		Information	PTS - Parktronic system																																	
A-CLASS	169		Information	MIF/UCI - Media interface																																	
A-CLASS	169		Information	IC - Instrument cluster																						V											V
A-CLASS	169		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	169		Information	CTEL/TEL - Cellular/Mobile telephone																																	
A-CLASS	169		Information	AUDIO/COMAND																																	
A-CLASS	169		Information	ASSYST PLUS - PLUS Active Service System																													V				
A-CLASS	169		Information	ASSYST Active Service System																																	
A-CLASS	169		Information	AGW - Audio gateway																																	
A-CLASS	169		Seat/Door	DCM-RR - Door control module rear right																																	
A-CLASS	169		Seat/Door	DCM-RL - Door control module rear left																																	
A-CLASS	169		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	169		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	169		Air Conditioning	AAC - Automatic air conditioning																							V										
A-CLASS	176		Drive	VG - Transfer case																																	
A-CLASS	176		Drive	ME/CDI/CNG - Engine control unit				V																									V				
A-CLASS	176		Drive	ETC - Electronic transmission control																																	
A-CLASS	176		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
A-CLASS	176		Drive	DTR - Distronic													V																				
A-CLASS	176		Drive	DSI - Direct select interface																																	
A-CLASS	176		Drive	PTCU - Common powertrain controller																																	
A-CLASS	176		Chassis	ABS/ESP - Electronic stability program								V										V															
A-CLASS	176		Chassis	ES - Electrical power steering											V																						
A-CLASS	176		Chassis	EFB - Electric parking brake										V																							
A-CLASS	176		Chassis	TPM - Tire pressure monitor																																	
A-CLASS	176		Body	SG-AWF - Collision prevention assist																																	
A-CLASS	176		Body	SCM [MRM] - Steering column module																																	
A-CLASS	176		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
A-CLASS	176		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
A-CLASS	176		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
A-CLASS	176		Body	Multifunction control unit																																	
A-CLASS	176		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	176		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
A-CLASS	176		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	176		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	176		Body	AHE - Trailer recognition																																	
A-CLASS	176		Body	AB - Airbag																																	
A-CLASS	176		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
A-CLASS	176		Information	ZAN - Audio/COMAND display																																	
A-CLASS	176		Information	TV - TV tuner																																	
A-CLASS	176		Information	SOUND - Sound system																																	
A-CLASS	176		Information	RFK - Backup camera														V		V																	
A-CLASS	176		Information	MFK - Multifunction camera																				V													
A-CLASS	176		Information	PTS - Parktronic system																																	
A-CLASS	176		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
A-CLASS	176		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
A-CLASS	176		Information	NAV - Navigation module																																	
A-CLASS	176		Information	MIF/UCI - Media interface																																	
A-CLASS	176		Information	IC - Instrument cluster																						V								V			
A-CLASS	176		Information	DTA - Mbrace or TELEAID/GPS Box																																	
A-CLASS	176		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	176		Information	COU [ZBE] - Audio/COMAND operating unit																																	
A-CLASS	176		Information	AUDIO/COMAND																																	
A-CLASS	176		Seat/Door	PSD/MSC - Sliding roof control																																	
A-CLASS	176		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
A-CLASS	176		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
A-CLASS	176		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	176		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	176		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	176		Air Conditioning	AAC - Automatic air conditioning					V	V																											
B-CLASS	245		Drive	ME/CDI/CNG - Engine control unit																													V				
B-CLASS	245		Drive	ETC - Electronic transmission control																																	
B-CLASS	245		Drive	ESM - Electronic selector module																																	
B-CLASS	245		Drive	Hydrogen tank control unit																																	
B-CLASS	245		Drive	High-temperature coolant pump control unit																																	
B-CLASS	245		Drive	Fuel cell control unit																																	
B-CLASS	245		Drive	Electric drive control unit																																	
B-CLASS	245		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	245		Drive	BSA - Belt-driven starter/alternator																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
B-CLASS	245		Drive	VECU - Power monitoring control unit																																	
B-CLASS	245		Chassis	ABS/ESP - Electronic stability program			V																							V							
B-CLASS	245		Chassis	ES - Electrical power steering																																	
B-CLASS	245		Chassis	VP - Vacuum pump brake booster																																	
B-CLASS	245		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	245		Body	WSS - Weight sensing system																																	
B-CLASS	245		Body	SG-DDW - DC/DC converter control unit																																	
B-CLASS	245		Body	SCM [MRM] - Steering column module																																	
B-CLASS	245		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
B-CLASS	245		Body	OCP - Overhead control panel																																	
B-CLASS	245		Body	Multifunction control unit																																	
B-CLASS	245		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	245		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	245		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	245		Body	CGW - Central gateway																																	
B-CLASS	245		Body	BNS/BMS - Battery sensor																																	
B-CLASS	245		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	245		Body	AHE - Trailer recognition																																	
B-CLASS	245		Body	AB - Airbag																																	
B-CLASS	245		Information	SOUND - Sound system																																	
B-CLASS	245		Information	PTS - Parktronic system																																	
B-CLASS	245		Information	NAV - Navigation module																																	
B-CLASS	245		Information	MIF/UCI - Media interface																																	
B-CLASS	245		Information	IC - Instrument cluster																						V											V
B-CLASS	245		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	245		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	245		Information	CTEL/TEL - Cellular/Mobile telephone																																	
B-CLASS	245		Information	CM - Compass module																																	
B-CLASS	245		Information	AUDIO/COMAND																																	
B-CLASS	245		Information	ASSYST PLUS - PLUS Active Service System																													V				
B-CLASS	245		Information	ASSYST Active Service System																																	
B-CLASS	245		Information	AGW - Audio gateway																																	
B-CLASS	245		Seat/Door	DCM-RR - Door control module rear right																																	
B-CLASS	245		Seat/Door	DCM-RL - Door control module rear left																																	
B-CLASS	245		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	245		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
B-CLASS	245		Air Conditioning	EKMK - Electric refrigerant compressor																																	
B-CLASS	245		Air Conditioning	AAC - Automatic air conditioning																							V										
B-CLASS	246		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	246		Drive	VG - Transfer case																																	
B-CLASS	246		Drive	ME/CDI/CNG - Engine control unit				V																									V				
B-CLASS	246		Drive	ETC - Electronic transmission control																																	
B-CLASS	246		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
B-CLASS	246		Drive	DTR - Distronic													V																				
B-CLASS	246		Drive	PTCU - Common powertrain controller																																	
B-CLASS	246		Chassis	ABS/ESP - Electronic stability program								V										V															
B-CLASS	246		Chassis	ES - Electrical power steering											V																						
B-CLASS	246		Chassis	EFB - Electric parking brake										V																							
B-CLASS	246		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	246		Body	BNS/BMS - Battery sensor																																	
B-CLASS	246		Body	SG-AWF - Collision prevention assist																																	
B-CLASS	246		Body	SCM [MRM] - Steering column module																																	
B-CLASS	246		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
B-CLASS	246		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
B-CLASS	246		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
B-CLASS	246		Body	Multifunction control unit																																	
B-CLASS	246		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
B-CLASS	246		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	246		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	246		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	246		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	246		Body	AHE - Trailer recognition																																	
B-CLASS	246		Body	AB - Airbag																																	
B-CLASS	246		Information	Sound generator for exhaust system																																	
B-CLASS	246		Information	Head-up display																																	
B-CLASS	246		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
B-CLASS	246		Information	ZAN - Audio/COMAND display																																	
B-CLASS	246		Information	TV - TV tuner																																	
B-CLASS	246		Information	SOUND - Sound system																																	
B-CLASS	246		Information	RFK - Backup camera														V		V																	
B-CLASS	246		Information	MFK - Multifunction camera																				V													
B-CLASS	246		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
B-CLASS	246		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
B-CLASS	246		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
B-CLASS	246		Information	NAV - Navigation module																																	
B-CLASS	246		Information	MIF/UCI - Media interface																																	
B-CLASS	246		Information	IC - Instrument cluster																						V								V			
B-CLASS	246		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	246		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	246		Information	COU [ZBE] - Audio/COMAND operating unit																																	
B-CLASS	246		Information	AUDIO/COMAND																																	
B-CLASS	246		Seat/Door	PSD/MSC - Sliding roof control																																	
B-CLASS	246		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
B-CLASS	246		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
B-CLASS	246		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	246		Seat/Door	DCM-FL - Door control module front left																																	
B-CLASS	246		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
B-CLASS	246		Air Conditioning	AAC - Automatic air conditioning					V	V																											
C-CLASS	202		Drive	ME/CDI/CNG - Engine control unit																								V									
C-CLASS	202		Drive	ETC - Electronic transmission control																																	
C-CLASS	202		Drive	ESM - Electronic selector module																																	
C-CLASS	202		Chassis	PSE - Pneumatic system equipment																																	
C-CLASS	202		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	202		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	202		Chassis	BAS - Brake assist																																	
C-CLASS	202		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	202		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	202		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	202		Body	OCP - Overhead control panel																																	
C-CLASS	202		Body	AB - Airbag																																	
C-CLASS	202		Information	PTS - Parktronic system																																	
C-CLASS	202		Information	NAV - Navigation module																																	
C-CLASS	202		Information	IC - Instrument cluster																																	
C-CLASS	202		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	202		Information	AUDIO/COMAND																																	
C-CLASS	202		Information	APS - Auto pilot system																																	
C-CLASS	202		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	202		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
C-CLASS	202		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	202		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	202		Air Conditioning	TSTH/STH - Stationary heater with remote control																					V												
C-CLASS	202		Air Conditioning	HB - Heater booster																					V												
C-CLASS	202		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	203		Drive	ME/CDI/CNG - Engine control unit																									V				V				
C-CLASS	203		Drive	ETC - Electronic transmission control																																	
C-CLASS	203		Drive	ESM - Electronic selector module																																	
C-CLASS	203		Drive	DTR - Distronic																																V	
C-CLASS	203		Chassis	ABS/ESP - Electronic stability program			V																							V							
C-CLASS	203		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	203		Chassis	BAS - Brake assist																																	
C-CLASS	203		Body	WSS - Weight sensing system																																	
C-CLASS	203		Body	UCP - Upper control panel																																	
C-CLASS	203		Body	System diagnosis																																	
C-CLASS	203		Body	SCM [MRM] - Steering column module																																V	
C-CLASS	203		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	203		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	203		Body	OCP - Overhead control panel																																	
C-CLASS	203		Body	Multifunction control unit																																	
C-CLASS	203		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	203		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	203		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	203		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	203		Body	CGW - Central gateway																																	
C-CLASS	203		Body	AHE - Trailer recognition																																	
C-CLASS	203		Body	AB - Airbag																																	
C-CLASS	203		Information	TV - TV tuner																																	
C-CLASS	203		Information	SOUND - Sound system																																	
C-CLASS	203		Information	PTS - Parktronic system																																	
C-CLASS	203		Information	NAV - Navigation module																																	
C-CLASS	203		Information	MIF/UCI - Media interface																																	
C-CLASS	203		Information	IC - Instrument cluster																						V											V
C-CLASS	203		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	203		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	203		Information	CTEL/TEL - Cellular/Mobile telephone																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
C-CLASS	203		Information	AUDIO/COMAND																																	
C-CLASS	203		Information	AGW - Audio gateway																																	
C-CLASS	203		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	203		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	203		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	203		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	203		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	203		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	203		Air Conditioning	TSTH/STH - Stationary heater with remote control																							V										
C-CLASS	203		Air Conditioning	AAC - Automatic air conditioning																						V											
C-CLASS	204		Drive	ME/CDI/CNG - Engine control unit				V																									V				
C-CLASS	204		Drive	ETC - Electronic transmission control																																	
C-CLASS	204		Drive	ESM - Electronic selector module																																	
C-CLASS	204		Drive	SCR - Selective catalytic reduction									V																								
C-CLASS	204		Drive	ISM - Intelligent servo module							V																										
C-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
C-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	204		Drive	DTR - Distronic													V																				
C-CLASS	204		Drive	AMG DRIVE UNIT																																	
C-CLASS	204		Drive	PTCU - Common powertrain controller																																	
C-CLASS	204		Chassis	ABS/ESP - Electronic stability program								V				V			V			V															
C-CLASS	204		Chassis	Suspension																																	
C-CLASS	204		Chassis	ES - Electrical power steering											V																						
C-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	204		Body	WSS - Weight sensing system																																	
C-CLASS	204		Body	SCM [MRM] - Steering column module																																	
C-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
C-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
C-CLASS	204		Body	OCP - Overhead control panel																																	
C-CLASS	204		Body	Multifunction control unit																																	
C-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	204		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
C-CLASS	204		Body	CGW - Central gateway																																	
C-CLASS	204		Body	AHE - Trailer recognition																																	
C-CLASS	204		Body	AB - Airbag																																	
C-CLASS	204		Information	Head-up display																																	
C-CLASS	204		Information	AVE-H - Rear audio video unit																																	
C-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
C-CLASS	204		Information	ZAN - Audio/COMAND display																																	
C-CLASS	204		Information	TV - TV tuner																																	
C-CLASS	204		Information	Sound generator for exhaust system																																	
C-CLASS	204		Information	SOUND - Sound system																																	
C-CLASS	204		Information	SGR - Radar sensors control unit																																	
C-CLASS	204		Information	360' - Camera																																	
C-CLASS	204		Information	MFK - Multifunction camera																				V													
C-CLASS	204		Information	RFK - Backup camera	V													V		V			V														
C-CLASS	204		Information	PTS - Parktronic system																																	
C-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	204		Information	NBR-RF - Right front range radar																																	
C-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	204		Information	NBR-LF - Left front range radar																																	
C-CLASS	204		Information	NAV - Navigation module																																	
C-CLASS	204		Information	MIF/UCI - Media interface																																	
C-CLASS	204		Information	ICI - InCar Internet																																	
C-CLASS	204		Information	IC - Instrument cluster																						V								V			
C-CLASS	204		Information	DVD player																																	
C-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
C-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
C-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
C-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	204		Information	AUDIO/COMAND																																	
C-CLASS	204		Information	AMG Performance Media																																	
C-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	204		Seat/Door	HKS - Tailgate control																																	
C-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
C-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																		
C-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																		
C-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																		
C-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																		
C-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																		
C-CLASS	204		Air Conditioning	AAC - Automatic air conditioning					V	V																												
C-CLASS	205		Drive	SCR - Selective catalytic reduction									V																									
C-CLASS	205		Drive	SG-EM - Power electronics																																		
C-CLASS	205		Drive	FSCU/FSCU-L - Control unit Fuel pump																																		
C-CLASS	205		Drive	HFPM - Haptic accelerator pedal module																																		
C-CLASS	205		Drive	DTR - Distronic																																		
C-CLASS	205		Drive	ISM - Intelligent servo module							V																											
C-CLASS	205		Drive	ME/CDI/CNG - Engine control unit				V																									V					
C-CLASS	205		Drive	ETC - Electronic transmission control																																		
C-CLASS	205		Drive	PTCU - Common powertrain controller																																		
C-CLASS	205		Chassis	TPM - Tire pressure monitor																																		
C-CLASS	205		Chassis	Suspension																																		
C-CLASS	205		Chassis	ABS/ESP - Electronic stability program																																		
C-CLASS	205		Chassis	ES - Electrical power steering																																		
C-CLASS	205		Chassis	EFB - Electric parking brake										V																								
C-CLASS	205		Information	TPAD - Touchpad																																		
C-CLASS	205		Information	DAB/SDAR - Digital/Satellite radio																																		
C-CLASS	205		Information	360' - Camera																																		
C-CLASS	205		Information	Sound generator for exhaust system																																		
C-CLASS	205		Information	SOUND - Sound system																																		
C-CLASS	205		Information	RFK - Backup camera																																		
C-CLASS	205		Information	SGR - Radar sensors control unit																																		
C-CLASS	205		Information	PTS - Parktronic system																																		
C-CLASS	205		Information	NBR-RF - Right front range radar																																		
C-CLASS	205		Information	NBR-LF - Left front range radar																																		
C-CLASS	205		Information	MFK - Multifunction camera																																		
C-CLASS	205		Information	NBR-LR/IRS-HLA - Left rear range radar																																		
C-CLASS	205		Information	NBR-RR/IRS-HRA - Right rear range radar																																		
C-CLASS	205		Information	Head-up display																																		
C-CLASS	205		Information	AUDIO/COMAND																																		
C-CLASS	205		Information	ZAN - Audio/COMAND display																																		

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
C-CLASS	205		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	205		Information	KAB - Camera cover																																	
C-CLASS	205		Information	IC - Instrument cluster																																	
C-CLASS	205		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	205		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
C-CLASS	205		Body	AHE - Trailer recognition																																	
C-CLASS	205		Body	SCM [MRM] - Steering column module																																	
C-CLASS	205		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	AB - Airbag																																	
C-CLASS	205		Body	Multifunction control unit																																	
C-CLASS	205		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	205		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	205		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	205		Body	SG-AWF - Collision prevention assist																																	
C-CLASS	205		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	205		Body	BNS/BMS - Battery sensor																																	
C-CLASS	205		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	205		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																														V			
C-CLASS	205		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	205		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	205		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	205		Seat/Door	HKS - Tailgate control																																	
C-CLASS	205		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	205		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	205		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	205		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	205		Seat/Door	RVC/VDS - Convertible roof control																																	
C-CLASS	205		Air Conditioning	AAC - Automatic air conditioning					V																												
E-CLASS	124		Drive	PMS/HFM/LH																																	
E-CLASS	124		Drive	ETC - Electronic transmission control																																	
E-CLASS	124		Drive	ISC - Idle speed control																																	
E-CLASS	124		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	124		Body	AB - Airbag																																	
E-CLASS	210		Drive	ME/CDI/CNG - Engine control unit																								V									
E-CLASS	210		Drive	ETC - Electronic transmission control																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
E-CLASS	210		Drive	ESM - Electronic selector module																																	
E-CLASS	210		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	210		Chassis	VP - Vacuum pump brake booster																																	
E-CLASS	210		Chassis	PSE - Pneumatic system equipment																																	
E-CLASS	210		Chassis	BAS - Brake assist																																	
E-CLASS	210		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	210		Body	OCP - Overhead control panel																																	
E-CLASS	210		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	210		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	210		Body	AB - Airbag																																	
E-CLASS	210		Information	TV - TV tuner																																	
E-CLASS	210		Information	PTS - Parktronic system																																	
E-CLASS	210		Information	NAV - Navigation module																																	
E-CLASS	210		Information	IC - Instrument cluster																						V											
E-CLASS	210		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	210		Information	AUDIO/COMAND																																	
E-CLASS	210		Information	APS - Auto pilot system																																	
E-CLASS	210		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	210		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	210		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	210		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	210		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	210		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	210		Air Conditioning	TSTH/STH - Stationary heater with remote control																					V												
E-CLASS	210		Air Conditioning	HB - Heater booster																					V												
E-CLASS	210		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	211		Drive	ME/CDI/CNG - Engine control unit																								V				V					
E-CLASS	211		Drive	ETC - Electronic transmission control																																	
E-CLASS	211		Drive	ESM - Electronic selector module																																	
E-CLASS	211		Drive	Natural gas control unit																																	
E-CLASS	211		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	211		Drive	DTR - Distronic																																V	
E-CLASS	211		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	211		Chassis	ABS/ESP - Electronic stability program			V																						V								
E-CLASS	211		Chassis	Suspension																																	
E-CLASS	211		Chassis	SBC - Sensotronic Brake Control																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
E-CLASS	211		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	211		Body	WSS - Weight sensing system																																	
E-CLASS	211		Body	UCP - Upper control panel																																	
E-CLASS	211		Body	System diagnosis																																	
E-CLASS	211		Body	SCM [MRM] - Steering column module																																V	
E-CLASS	211		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	211		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
E-CLASS	211		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	211		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	OCP - Overhead control panel																																	
E-CLASS	211		Body	Multifunction control unit																																	
E-CLASS	211		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	211		Body	LAE [LAA] - Loading floor automatically extendable																																	
E-CLASS	211		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	211		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	211		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	211		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	211		Body	CGW - Central gateway																																	
E-CLASS	211		Body	BNS/BMS - Battery sensor																																	
E-CLASS	211		Body	AHE - Trailer recognition																																	
E-CLASS	211		Body	AB - Airbag																																	
E-CLASS	211		Information	TV - TV tuner																																	
E-CLASS	211		Information	SOUND - Sound system																																	
E-CLASS	211		Information	PTS - Parktronic system																																	
E-CLASS	211		Information	MIF/UCI - Media interface																																	
E-CLASS	211		Information	IC - Instrument cluster																						V											V
E-CLASS	211		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	211		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	211		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	211		Information	AUDIO/COMAND																																	
E-CLASS	211		Information	ASSYST PLUS - PLUS Active Service System																													V				
E-CLASS	211		Information	ASSYST Active Service System																																	
E-CLASS	211		Information	AGW - Audio gateway																																	
E-CLASS	211		Seat/Door	REDC/RWT - Rear end door control module																																	
E-CLASS	211		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
E-CLASS	211		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	211		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	211		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	211		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	211		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	211		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	211		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	211		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	211		Air Conditioning	AAC - Automatic air conditioning																							V										
E-CLASS	207		Drive	SG-EM - Power electronics																																	
E-CLASS	207		Drive	SCR - Selective catalytic reduction									V																								
E-CLASS	207		Drive	ME/CDI/CNG - Engine control unit				V																									V				
E-CLASS	207		Drive	ETC - Electronic transmission control																																	
E-CLASS	207		Drive	ESM - Electronic selector module																																	
E-CLASS	207		Drive	ISM - Intelligent servo module							V																										
E-CLASS	207		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	207		Drive	DTR - Distronic													V																				
E-CLASS	207		Drive	DSI - Direct select interface																																	
E-CLASS	207		Drive	AMG DRIVE UNIT																																	
E-CLASS	207		Chassis	ABS/ESP - Electronic stability program								V										V															
E-CLASS	207		Chassis	Suspension																																	
E-CLASS	207		Chassis	ES - Electrical power steering											V																						
E-CLASS	207		Chassis	FWGW - Chassis gateway																																	
E-CLASS	207		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	207		Body	BNS/BMS - Battery sensor																																	
E-CLASS	207		Body	WSS - Weight sensing system																																	
E-CLASS	207		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	207		Body	SCM [MRM] - Steering column module																																	
E-CLASS	207		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	207		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	207		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
E-CLASS	207		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
E-CLASS	207		Body	Multifunction control unit																																	
E-CLASS	207		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
E-CLASS	207		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
E-CLASS	207		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	207		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	207		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	207		Body	CGW - Central gateway																																	
E-CLASS	207		Body	AHE - Trailer recognition																																	
E-CLASS	207		Body	AB - Airbag																																	
E-CLASS	207		Information	NBR-RF - Right front range radar																																	
E-CLASS	207		Information	NBR-LF - Left front range radar																																	
E-CLASS	207		Information	AVE-H - Rear audio video unit																																	
E-CLASS	207		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	207		Information	ZAN - Audio/COMAND display																																	
E-CLASS	207		Information	TV - TV tuner																																	
E-CLASS	207		Information	SOUND - Sound system																																	
E-CLASS	207		Information	SGR - Radar sensors control unit																																	
E-CLASS	207		Information	360' - Camera																																	
E-CLASS	207		Information	MFK - Multifunction camera																				V													
E-CLASS	207		Information	RFK - Backup camera	V													V		V			V														
E-CLASS	207		Information	PTS - Parktronic system																																	
E-CLASS	207		Information	NSA - Night View Assist																																	
E-CLASS	207		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	207		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	207		Information	NAV - Navigation module																																	
E-CLASS	207		Information	MIF/UCI - Media interface																																	
E-CLASS	207		Information	ICI - InCar Internet																																	
E-CLASS	207		Information	IC - Instrument cluster																						V								V			
E-CLASS	207		Information	DVD player																																	
E-CLASS	207		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	207		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	207		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	207		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	207		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	207		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	207		Information	AUDIO/COMAND																																	
E-CLASS	207		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	207		Seat/Door	PSD/MSC - Sliding roof control																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
E-CLASS	207		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																		
E-CLASS	207		Seat/Door	ESA Driver - Electric seat adjustment Driver																																		
E-CLASS	207		Seat/Door	DCM-FR - Door control module front right																																		
E-CLASS	207		Seat/Door	DCM-FL - Door control module front left																																		
E-CLASS	207		Air Conditioning	EKMK - Electric refrigerant compressor																																		
E-CLASS	207		Air Conditioning	TSTH/STH - Stationary heater with remote control																																		
E-CLASS	207		Air Conditioning	AAC - Automatic air conditioning					V	V																												
E-CLASS	212		Drive	SG-EM - Power electronics																																		
E-CLASS	212		Drive	Compressed Natural Gas Control Module																																		
E-CLASS	212		Drive	ME/CDI/CNG - Engine control unit				V																									V					
E-CLASS	212		Drive	ETC - Electronic transmission control																																		
E-CLASS	212		Drive	ESM - Electronic selector module																																		
E-CLASS	212		Drive	SCR - Selective catalytic reduction									V																									
E-CLASS	212		Drive	ISM - Intelligent servo module							V																											
E-CLASS	212		Drive	FSCU/FSCU-L - Control unit Fuel pump																																		
E-CLASS	212		Drive	DTR - Distronic													V																					
E-CLASS	212		Drive	DSI - Direct select interface																																		
E-CLASS	212		Drive	AMG DRIVE UNIT																																		
E-CLASS	212		Chassis	ABS/ESP - Electronic stability program								V				V			V			V																
E-CLASS	212		Chassis	Suspension																																		
E-CLASS	212		Chassis	ES - Electrical power steering											V																							
E-CLASS	212		Chassis	FWGW - Chassis gateway																																		
E-CLASS	212		Chassis	TPM - Tire pressure monitor																																		
E-CLASS	212		Body	BNS/BMS - Battery sensor																																		
E-CLASS	212		Body	WSS - Weight sensing system																																		
E-CLASS	212		Body	SG-AWF - Collision prevention assist																																		
E-CLASS	212		Body	SCM [MRM] - Steering column module																																		
E-CLASS	212		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																		
E-CLASS	212		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																		
E-CLASS	212		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V												
E-CLASS	212		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V												
E-CLASS	212		Body	OCP - Overhead control panel																																		
E-CLASS	212		Body	Multifunction control unit																																		
E-CLASS	212		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																		
E-CLASS	212		Body	HSW/LRH - Steering wheel heater																																		
E-CLASS	212		Body	HS/AIRSCARF - Seat heater/Air scarf system																																		

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
E-CLASS	212		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	212		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	212		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	212		Body	CGW - Central gateway																																	
E-CLASS	212		Body	AHE - Trailer recognition																																	
E-CLASS	212		Body	AB - Airbag																																	
E-CLASS	212		Information	Head-up display																																	
E-CLASS	212		Information	AVE-H - Rear audio video unit																																	
E-CLASS	212		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	212		Information	ZAN - Audio/COMAND display																																	
E-CLASS	212		Information	TV - TV tuner																																	
E-CLASS	212		Information	SOUND - Sound system																																	
E-CLASS	212		Information	SGR - Radar sensors control unit																																	
E-CLASS	212		Information	360' - Camera																																	
E-CLASS	212		Information	MFK - Multifunction camera																				V													
E-CLASS	212		Information	RFK - Backup camera	V													V		V			V														
E-CLASS	212		Information	PTS - Parktronic system																																	
E-CLASS	212		Information	NSA - Night View Assist																																	
E-CLASS	212		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	212		Information	NBR-RF - Right front range radar																																	
E-CLASS	212		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	212		Information	NBR-LF - Left front range radar																																	
E-CLASS	212		Information	NAV - Navigation module																																	
E-CLASS	212		Information	MIF/UCI - Media interface																																	
E-CLASS	212		Information	ICI - InCar Internet																																	
E-CLASS	212		Information	IC - Instrument cluster																						V								V			
E-CLASS	212		Information	DVD player																																	
E-CLASS	212		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	212		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	212		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	212		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	212		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	212		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	212		Information	AUDIO/COMAND																																	
E-CLASS	212		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	212		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
E-CLASS	212		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																		
E-CLASS	212		Seat/Door	ESA Driver - Electric seat adjustment Driver																																		
E-CLASS	212		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																		
E-CLASS	212		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																		
E-CLASS	212		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																		
E-CLASS	212		Seat/Door	DCM-RR - Door control module rear right																																		
E-CLASS	212		Seat/Door	DCM-RL - Door control module rear left																																		
E-CLASS	212		Seat/Door	DCM-FR - Door control module front right																																		
E-CLASS	212		Seat/Door	DCM-FL - Door control module front left																																		
E-CLASS	212		Air Conditioning	EKMK - Electric refrigerant compressor																																		
E-CLASS	212		Air Conditioning	TSTH/STH - Stationary heater with remote control																																		
E-CLASS	212		Air Conditioning	AAC - Automatic air conditioning					V	V																												
E-CLASS	213		Drive	SCR - Selective catalytic reduction									V																									
E-CLASS	213		Drive	DTR - Distronic																																		
E-CLASS	213		Drive	FSCU/FSCU-L - Control unit Fuel pump																																		
E-CLASS	213		Drive	HFPM - Haptic accelerator pedal module																																		
E-CLASS	213		Drive	AMG DRIVE UNIT																																		
E-CLASS	213		Drive	PTCU - Common powertrain controller																																		
E-CLASS	213		Drive	ME/CDI/CNG - Engine control unit				V																									V					
E-CLASS	213		Drive	ETC - Electronic transmission control																																		
E-CLASS	213		Chassis	TPM - Tire pressure monitor																																		
E-CLASS	213		Chassis	AIRMATIC PLUS																																		
E-CLASS	213		Chassis	ES - Electrical power steering																																		
E-CLASS	213		Chassis	Suspension																																		
E-CLASS	213		Chassis	ABS/ESP - Electronic stability program																																		
E-CLASS	213		Body	MTAS - Mobile phone cradle																																		
E-CLASS	213		Body	AHE - Trailer recognition																																		
E-CLASS	213		Body	SCM [MRM] - Steering column module																																		
E-CLASS	213		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																		
E-CLASS	213		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																		
E-CLASS	213		Body	SG-LML-VR - LED matrix of right front lamp unit																																		
E-CLASS	213		Body	SG-LML-VL - LED matrix of left front lamp unit																																		
E-CLASS	213		Body	AB - Airbag																																		
E-CLASS	213		Body	OCP - Overhead control panel																																		
E-CLASS	213		Body	Multifunction control unit																																		
E-CLASS	213		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																		

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
E-CLASS	213		Body	SG-DDW - DC/DC converter control unit																																	
E-CLASS	213		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	213		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	213		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	213		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	213		Body	BNS/BMS - Battery sensor																																	
E-CLASS	213		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	213		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																														V			
E-CLASS	213		Body	AML - Ambiance light																																	
E-CLASS	213		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	213		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	213		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
E-CLASS	213		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
E-CLASS	213		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	213		Seat/Door	HKS - Tailgate control																																	
E-CLASS	213		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	213		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	213		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	213		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	213		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	213		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	213		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	213		Information	TPAD - Touchpad																																	
E-CLASS	213		Information	Sound generator for exhaust system																																	
E-CLASS	213		Information	SOUND - Sound system																																	
E-CLASS	213		Information	RFK - Backup camera																																	
E-CLASS	213		Information	PTS - Parktronic system																																	
E-CLASS	213		Information	MFK - Multifunction camera																																	
E-CLASS	213		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	213		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	213		Information	SGR - Radar sensors control unit																																	
E-CLASS	213		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
E-CLASS	213		Information	Head-up display																																	
E-CLASS	213		Information	AUDIO/COMAND																																	
E-CLASS	213		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	213		Information	ZAN - Audio/COMAND display																																	
E-CLASS	213		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	213		Air Conditioning	AAC - Automatic air conditioning					V																												
S-CLASS	140		Drive	ASF																																	
S-CLASS	140		Drive	ERE																																	
S-CLASS	140		Drive	ME1LI																																	
S-CLASS	140		Drive	ME1RE																																	
S-CLASS	140		Drive	HFM/ME2/LH																																	
S-CLASS	140		Drive	ETC - Electronic transmission control																																	
S-CLASS	140		Drive	ISC - Idle speed control																																	
S-CLASS	140		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	140		Chassis	BAS - Brake assist																																	
S-CLASS	140		Body	PSE - Pneumatic system equipment																																	
S-CLASS	140		Body	AB - Airbag																																	
S-CLASS	140		Information	PTS - Parktronic system																																	
S-CLASS	140		Information	IC - Instrument cluster																																	
S-CLASS	140		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	220		Drive	ME/CDI/CNG - Engine control unit																								V				V					
S-CLASS	220		Drive	ETC - Electronic transmission control																																	
S-CLASS	220		Drive	ESM - Electronic selector module																																	
S-CLASS	220		Drive	DTR - Distronic																																V	
S-CLASS	220		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	220		Chassis	Suspension																	V																
S-CLASS	220		Chassis	PSE - Pneumatic system equipment																																	
S-CLASS	220		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	220		Body	UCP - Upper control panel																																	
S-CLASS	220		Body	System diagnosis																																	
S-CLASS	220		Body	SCM [MRM] - Steering column module																																	
S-CLASS	220		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	220		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
S-CLASS	220		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	220		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	220		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
S-CLASS	220		Body	OCP - Overhead control panel																																	
S-CLASS	220		Body	Multifunction control unit																																	
S-CLASS	220		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	220		Body	HSW/LRH - Steering wheel heater																																	
S-CLASS	220		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	220		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	220		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	220		Body	CGW - Central gateway																																	
S-CLASS	220		Body	AHE - Trailer recognition																																	
S-CLASS	220		Body	AB - Airbag																																	
S-CLASS	220		Information	TV - TV tuner																																	
S-CLASS	220		Information	PTS - Parktronic system																																	
S-CLASS	220		Information	NAV - Navigation module																																	
S-CLASS	220		Information	IC - Instrument cluster																						V											
S-CLASS	220		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	220		Information	AUDIO/COMAND																																	
S-CLASS	220		Information	AGW - Audio gateway																																	
S-CLASS	220		Seat/Door	OSB-R - Multicontour backrest rear																																	
S-CLASS	220		Seat/Door	OSB-FL - Multicontour backrest front left																																	
S-CLASS	220		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	220		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	220		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	220		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	220		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	220		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	220		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	220		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	220		Air Conditioning	TSTH/STH - Stationary heater with remote control																					V												
S-CLASS	220		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	220		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	221		Drive	ME/CDI/CNG - Engine control unit				V																									V				
S-CLASS	221		Drive	ETC - Electronic transmission control																																	
S-CLASS	221		Drive	SCR - Selective catalytic reduction									V																								
S-CLASS	221		Drive	ISM - Intelligent servo module							V																										

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
S-CLASS	221		Drive	HSG - Hybrid control unit																																	
S-CLASS	221		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	221		Drive	DTR - Distronic													V																				
S-CLASS	221		Chassis	ABS/ESP - Electronic stability program								V				V			V			V															
S-CLASS	221		Chassis	Suspension																																	
S-CLASS	221		Chassis	ES - Electrical power steering																																	
S-CLASS	221		Chassis	EFB - Electric parking brake																																	
S-CLASS	221		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	221		Body	WSS - Weight sensing system																																	
S-CLASS	221		Body	UCP - Upper control panel																																	
S-CLASS	221		Body	System diagnosis																																	
S-CLASS	221		Body	SG-DDW - DC/DC converter control unit																																	
S-CLASS	221		Body	SCM [MRM] - Steering column module																																	
S-CLASS	221		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	221		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	221		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
S-CLASS	221		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
S-CLASS	221		Body	OCP - Overhead control panel																																	
S-CLASS	221		Body	Multifunction control unit																																	
S-CLASS	221		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	221		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	221		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	221		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	221		Body	CGW - Central gateway																																	
S-CLASS	221		Body	BNS/BMS - Battery sensor																																	
S-CLASS	221		Body	AHE - Trailer recognition																																	
S-CLASS	221		Body	AB - Airbag																																	
S-CLASS	221		Information	ZAN - Audio/COMAND display																																	
S-CLASS	221		Information	VCS - Voice control																																	
S-CLASS	221		Information	TV - TV tuner																																	
S-CLASS	221		Information	Tuner - Standard tuner																																	
S-CLASS	221		Information	SOUND - Sound system																																	
S-CLASS	221		Information	SGR - Radar sensors control unit																																	
S-CLASS	221		Information	MFK - Multifunction camera																				V													
S-CLASS	221		Information	RFK - Backup camera	V																		V														
S-CLASS	221		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
S-CLASS	221		Information	NSA - Night View Assist																																	
S-CLASS	221		Information	NBR-LF - Left front range radar																																	
S-CLASS	221		Information	NAV - Navigation module																																	
S-CLASS	221		Information	MIF/UCI - Media interface																																	
S-CLASS	221		Information	ICI - InCar Internet																																	
S-CLASS	221		Information	IC - Instrument cluster																																	
S-CLASS	221		Information	DVD player																																	
S-CLASS	221		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	221		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	221		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	221		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	221		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	221		Information	AVE-H - Rear audio video unit																																	
S-CLASS	221		Information	AUDIO/COMAND																																	
S-CLASS	221		Information	ASSYST PLUS - PLUS Active Service System																																	
S-CLASS	221		Information	ASSYST Active Service System																																	
S-CLASS	221		Seat/Door	TSG-MR - Right center door control unit																																	
S-CLASS	221		Seat/Door	TSG-ML - Left center door control unit																																	
S-CLASS	221		Seat/Door	TLC/GTO - Garage door opener																																	
S-CLASS	221		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	221		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
S-CLASS	221		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
S-CLASS	221		Seat/Door	HKS - Tailgate control																																	
S-CLASS	221		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	221		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	221		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	221		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	221		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	221		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	221		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	221		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	221		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	221		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	221		Air Conditioning	HBF - Rear control panel																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
S-CLASS	221		Air Conditioning	AAC - Automatic air conditioning																																		
S-CLASS	217		Drive	SCR - Selective catalytic reduction									V																									
S-CLASS	217		Drive	SG-EM - Power electronics																																		
S-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																		
S-CLASS	217		Drive	DTR - Distronic																																		
S-CLASS	217		Drive	ISM - Intelligent servo module							V																											
S-CLASS	217		Drive	PTCU - Common powertrain controller																																		
S-CLASS	217		Drive	ME/CDI/CNG - Engine control unit				V																									V					
S-CLASS	217		Drive	ETC - Electronic transmission control																																		
S-CLASS	217		Chassis	TPM - Tire pressure monitor																																		
S-CLASS	217		Chassis	ABS/ESP - Electronic stability program																																		
S-CLASS	217		Chassis	ES - Electrical power steering																																		
S-CLASS	217		Chassis	Suspension																																		
S-CLASS	217		Chassis	EFB - Electric parking brake										V																								
S-CLASS	217		Information	TPAD - Touchpad																																		
S-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																		
S-CLASS	217		Information	360' - Camera																																		
S-CLASS	217		Information	SOUND - Sound system																																		
S-CLASS	217		Information	RFK - Backup camera																																		
S-CLASS	217		Information	SGR - Radar sensors control unit																																		
S-CLASS	217		Information	PTS - Parktronic system																																		
S-CLASS	217		Information	NSA - Night View Assist																																		
S-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																		
S-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																		
S-CLASS	217		Information	NBR-RF - Right front range radar																																		
S-CLASS	217		Information	NBR-LF - Left front range radar																																		
S-CLASS	217		Information	MFK - Multifunction camera																																		
S-CLASS	217		Information	Head-up display																																		
S-CLASS	217		Information	AUDIO/COMAND																																		
S-CLASS	217		Information	ZAN - Audio/COMAND display																																		
S-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																		
S-CLASS	217		Information	KAB - Camera cover																																		
S-CLASS	217		Information	IC - Instrument cluster																																		
S-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																		
S-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																		
S-CLASS	217		Body	SCM [MRM] - Steering column module																																		

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
S-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	AB - Airbag																																	
S-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	217		Body	BNS/BMS - Battery sensor																																	
S-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																														V			
S-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	217		Seat/Door	HKS - Tailgate control																																	
S-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
S-CLASS	217		Air Conditioning	AAC - Automatic air conditioning					V																												
S-CLASS	222		Drive	SCR - Selective catalytic reduction									V																								
S-CLASS	222		Drive	SG-EM - Power electronics																																	
S-CLASS	222		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	222		Drive	DTR - Distronic																																	
S-CLASS	222		Drive	ISM - Intelligent servo module							V																										
S-CLASS	222		Drive	PTCU - Common powertrain controller																																	
S-CLASS	222		Drive	ME/CDI/CNG - Engine control unit				V																								V					
S-CLASS	222		Drive	ETC - Electronic transmission control																																	
S-CLASS	222		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	222		Chassis	ES - Electrical power steering																																	
S-CLASS	222		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	222		Chassis	Suspension																																	
S-CLASS	222		Chassis	EFB - Electric parking brake										V																							
S-CLASS	222		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
S-CLASS	222		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	222		Information	360' - Camera																																	
S-CLASS	222		Information	Sound generator for exhaust system																																	
S-CLASS	222		Information	SOUND - Sound system																																	
S-CLASS	222		Information	RFK - Backup camera																																	
S-CLASS	222		Information	SGR - Radar sensors control unit																																	
S-CLASS	222		Information	PTS - Parktronic system																																	
S-CLASS	222		Information	NSA - Night View Assist																																	
S-CLASS	222		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	222		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	222		Information	NBR-RF - Right front range radar																																	
S-CLASS	222		Information	NBR-LF - Left front range radar																																	
S-CLASS	222		Information	MFK - Multifunction camera																																	
S-CLASS	222		Information	Head-up display																																	
S-CLASS	222		Information	AUDIO/COMAND																																	
S-CLASS	222		Information	AVE-H - Rear audio video unit																																	
S-CLASS	222		Information	ZAN - Audio/COMAND display																																	
S-CLASS	222		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	222		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	222		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	222		Information	KAB - Camera cover																																	
S-CLASS	222		Information	IC - Instrument cluster																																	
S-CLASS	222		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	222		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	222		Body	AHE - Trailer recognition																																	
S-CLASS	222		Body	SCM [MRM] - Steering column module																																	
S-CLASS	222		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	AB - Airbag																																	
S-CLASS	222		Body	Multifunction control unit																																	
S-CLASS	222		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	222		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	222		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	222		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
S-CLASS	222		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	222		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
S-CLASS	222		Body	BNS/BMS - Battery sensor																																	
S-CLASS	222		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	222		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																														V			
S-CLASS	222		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	222		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	222		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
S-CLASS	222		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
S-CLASS	222		Seat/Door	HKS - Tailgate control																																	
S-CLASS	222		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	222		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	222		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	222		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	222		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	222		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	222		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	222		Air Conditioning	AAC - Automatic air conditioning					V																												
G-CLASS	461 - 38P Connector		Drive	EVE																																	
G-CLASS	461 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 38P Connector		Information	IC - Instrument cluster																																	
G-CLASS	461 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	461 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit				V																								V					
G-CLASS	461 - 16P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	461 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	461 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	461 - 16P Connector		Chassis	ABS/ESP - Electronic stability program			V																						V								
G-CLASS	461 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	461 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	461 - 16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
G-CLASS	461 - 16P Connector		Body	CGW - Central gateway																																	
G-CLASS	461 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 16P Connector		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
G-CLASS	461 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	461 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	461 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																					V												
G-CLASS	463 - 38P Connector		Drive	ME/CDI/CNG - Engine control unit																									V								
G-CLASS	463 - 38P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	463 - 38P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 38P Connector		Drive	CC - Cruise control																																	
G-CLASS	463 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	463 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 38P Connector		Information	IC - Instrument cluster																						V											
G-CLASS	463 - 38P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 38P Connector		Information	APS - Auto pilot system																																	
G-CLASS	463 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																					V												
G-CLASS	463 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit				V																					V				V				
G-CLASS	463 - 16P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	463 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	463 - 16P Connector		Drive	SCR - Selective catalytic reduction									V																								
G-CLASS	463 - 16P Connector		Drive	ISM - Intelligent servo module							V																										
G-CLASS	463 - 16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
G-CLASS	463 - 16P Connector		Drive	DTR - Distronic													V																				
G-CLASS	463 - 16P Connector		Drive	DSI - Direct select interface																																	
G-CLASS	463 - 16P Connector		Chassis	ABS/ESP - Electronic stability program			V					V										V								V							
G-CLASS	463 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	463 - 16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
G-CLASS	463 - 16P Connector		Body	UCP - Upper control panel																																	
G-CLASS	463 - 16P Connector		Body	SCM [MRM] - Steering column module																																V	
G-CLASS	463 - 16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
G-CLASS	463 - 16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
G-CLASS	463 - 16P Connector		Body	OCP - Overhead control panel																																	
G-CLASS	463 - 16P Connector		Body	Multifunction control unit																																	
G-CLASS	463 - 16P Connector		Body	HSW/LRH - Steering wheel heater																																	
G-CLASS	463 - 16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
G-CLASS	463 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	463 - 16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
G-CLASS	463 - 16P Connector		Body	AHE - Trailer recognition																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
G-CLASS	463 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 16P Connector		Information	ZAN - Audio/COMAND display																																	
G-CLASS	463 - 16P Connector		Information	TV - TV tuner																																	
G-CLASS	463 - 16P Connector		Information	SOUND - Sound system																																	
G-CLASS	463 - 16P Connector		Information	PTS - Parktronic system																																	
G-CLASS	463 - 16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NAV - Navigation module																																	
G-CLASS	463 - 16P Connector		Information	MIF/UCI - Media interface																																	
G-CLASS	463 - 16P Connector		Information	IC - Instrument cluster																						V								V			V
G-CLASS	463 - 16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
G-CLASS	463 - 16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
G-CLASS	463 - 16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
G-CLASS	463 - 16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
G-CLASS	463 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	463 - 16P Connector		Seat/Door	HS - Seat heater																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RR - Door control module rear right																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RL - Door control module rear left																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FR - Door control module front right																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FL - Door control module front left																																	
G-CLASS	463 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																								V									
G-CLASS	463 - 16P Connector		Air Conditioning	AAC - Automatic air conditioning					V	V																	V										
GLA-CLASS	156		Drive	VG - Transfer case																																	
GLA-CLASS	156		Drive	ME/CDI/CNG - Engine control unit				V																									V				
GLA-CLASS	156		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLA-CLASS	156		Drive	ETC - Electronic transmission control																																	
GLA-CLASS	156		Drive	DTR - Distronic													V																				
GLA-CLASS	156		Drive	DSI - Direct select interface																																	
GLA-CLASS	156		Drive	PTCU - Common powertrain controller																																	
GLA-CLASS	156		Chassis	ABS/ESP - Electronic stability program								V										V															
GLA-CLASS	156		Chassis	ES - Electrical power steering											V																						
GLA-CLASS	156		Chassis	EFB - Electric parking brake										V																							
GLA-CLASS	156		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
GLA-CLASS	156		Body	SG-AWF - Collision prevention assist																																	
GLA-CLASS	156		Body	SCM [MRM] - Steering column module																																	
GLA-CLASS	156		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLA-CLASS	156		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
GLA-CLASS	156		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
GLA-CLASS	156		Body	Multifunction control unit																																	
GLA-CLASS	156		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLA-CLASS	156		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLA-CLASS	156		Body	EZS/EIS - Electronic ignition lock																																	
GLA-CLASS	156		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLA-CLASS	156		Body	AHE - Trailer recognition																																	
GLA-CLASS	156		Body	AB - Airbag																																	
GLA-CLASS	156		Information	Head-up display																																	
GLA-CLASS	156		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLA-CLASS	156		Information	KAB - Camera cover																																	
GLA-CLASS	156		Information	ZAN - Audio/COMAND display																																	
GLA-CLASS	156		Information	TV - TV tuner																																	
GLA-CLASS	156		Information	SOUND - Sound system																																	
GLA-CLASS	156		Information	RFK - Backup camera														V		V																	
GLA-CLASS	156		Information	MFK - Multifunction camera																				V													
GLA-CLASS	156		Information	PTS - Parktronic system																																	
GLA-CLASS	156		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLA-CLASS	156		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLA-CLASS	156		Information	NAV - Navigation module																																	
GLA-CLASS	156		Information	MIF/UCI - Media interface																																	
GLA-CLASS	156		Information	IC - Instrument cluster																						V								V			
GLA-CLASS	156		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLA-CLASS	156		Information	DAB/SDAR - Digital/Satellite radio																																	
GLA-CLASS	156		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLA-CLASS	156		Information	AUDIO/COMAND																																	
GLA-CLASS	156		Seat/Door	HKS - Tailgate control																																	
GLA-CLASS	156		Seat/Door	PSD/MSC - Sliding roof control																																	
GLA-CLASS	156		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLA-CLASS	156		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLA-CLASS	156		Seat/Door	DCM-FR - Door control module front right																																	
GLA-CLASS	156		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
GLA-CLASS	156		Air Conditioning	TSTH/STH - Stationary heater with remote control																																		
GLA-CLASS	156		Air Conditioning	AAC - Automatic air conditioning					V	V																												
GLK-CLASS	204		Drive	ME/CDI/CNG - Engine control unit				V																									V					
GLK-CLASS	204		Drive	ETC - Electronic transmission control																																		
GLK-CLASS	204		Drive	ESM - Electronic selector module																																		
GLK-CLASS	204		Drive	SCR - Selective catalytic reduction									V																									
GLK-CLASS	204		Drive	PTCU - Common powertrain controller																																		
GLK-CLASS	204		Drive	ISM - Intelligent servo module							V																											
GLK-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																		
GLK-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																		
GLK-CLASS	204		Drive	DTR - Distronic													V																					
GLK-CLASS	204		Drive	AMG DRIVE UNIT																																		
GLK-CLASS	204		Chassis	ABS/ESP - Electronic stability program								V				V			V			V																
GLK-CLASS	204		Chassis	Suspension																																		
GLK-CLASS	204		Chassis	ES - Electrical power steering											V																							
GLK-CLASS	204		Chassis	TPM - Tire pressure monitor																																		
GLK-CLASS	204		Body	WSS - Weight sensing system																																		
GLK-CLASS	204		Body	SCM [MRM] - Steering column module																																		
GLK-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																		
GLK-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																		
GLK-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V												
GLK-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V												
GLK-CLASS	204		Body	OCP - Overhead control panel																																		
GLK-CLASS	204		Body	Multifunction control unit																																		
GLK-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																		
GLK-CLASS	204		Body	Headlamp-R - Headlamp control unit																																		
GLK-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																																		
GLK-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																		
GLK-CLASS	204		Body	CGW - Central gateway																																		
GLK-CLASS	204		Body	AHE - Trailer recognition																																		
GLK-CLASS	204		Body	AB - Airbag																																		
GLK-CLASS	204		Information	Head-up display																																		
GLK-CLASS	204		Information	AVE-H - Rear audio video unit																																		
GLK-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																		
GLK-CLASS	204		Information	ZAN - Audio/COMAND display																																		
GLK-CLASS	204		Information	TV - TV tuner																																		

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
GLK-CLASS	204		Information	Sound generator for exhaust system																																	
GLK-CLASS	204		Information	SOUND - Sound system																																	
GLK-CLASS	204		Information	SGR - Radar sensors control unit																																	
GLK-CLASS	204		Information	360' - Camera																																	
GLK-CLASS	204		Information	MFK - Multifunction camera																				V													
GLK-CLASS	204		Information	RFK - Backup camera	V													V		V			V														
GLK-CLASS	204		Information	PTS - Parktronic system																																	
GLK-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLK-CLASS	204		Information	NBR-RF - Right front range radar																																	
GLK-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLK-CLASS	204		Information	NBR-LF - Left front range radar																																	
GLK-CLASS	204		Information	NAV - Navigation module																																	
GLK-CLASS	204		Information	MIF/UCI - Media interface																																	
GLK-CLASS	204		Information	ICI - InCar Internet																																	
GLK-CLASS	204		Information	IC - Instrument cluster																						V								V			
GLK-CLASS	204		Information	DVD player																																	
GLK-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLK-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
GLK-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
GLK-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
GLK-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GLK-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLK-CLASS	204		Information	AUDIO/COMAND																																	
GLK-CLASS	204		Information	AMG Performance Media																																	
GLK-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
GLK-CLASS	204		Seat/Door	HKS - Tailgate control																																	
GLK-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLK-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLK-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
GLK-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
GLK-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
GLK-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
GLK-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLK-CLASS	204		Air Conditioning	AAC - Automatic air conditioning					V	V																											
GLC-CLASS	253		Drive	SCR - Selective catalytic reduction									V																								
GLC-CLASS	253		Drive	SG-EM - Power electronics																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
GLC-CLASS	253		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLC-CLASS	253		Drive	DTR - Distronic																																	
GLC-CLASS	253		Drive	ISM - Intelligent servo module							V																										
GLC-CLASS	253		Drive	PTCU - Common powertrain controller																																	
GLC-CLASS	253		Drive	ME/CDI/CNG - Engine control unit				V																								V					
GLC-CLASS	253		Drive	ETC - Electronic transmission control																																	
GLC-CLASS	253		Chassis	TPM - Tire pressure monitor																																	
GLC-CLASS	253		Chassis	AIRMATIC PLUS																																	
GLC-CLASS	253		Chassis	ES - Electrical power steering																																	
GLC-CLASS	253		Chassis	Suspension																																	
GLC-CLASS	253		Chassis	ABS/ESP - Electronic stability program																																	
GLC-CLASS	253		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLC-CLASS	253		Body	AHE - Trailer recognition																																	
GLC-CLASS	253		Body	SCM [MRM] - Steering column module																																	
GLC-CLASS	253		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	AB - Airbag																																	
GLC-CLASS	253		Body	Multifunction control unit																																	
GLC-CLASS	253		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLC-CLASS	253		Body	Headlamp-R - Headlamp control unit																																	
GLC-CLASS	253		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLC-CLASS	253		Body	SG-AWF - Collision prevention assist																																	
GLC-CLASS	253		Body	EZS/EIS - Electronic ignition lock																																	
GLC-CLASS	253		Body	BNS/BMS - Battery sensor																																	
GLC-CLASS	253		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLC-CLASS	253		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																														V			
GLC-CLASS	253		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLC-CLASS	253		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLC-CLASS	253		Seat/Door	PSD/MSC - Sliding roof control																																	
GLC-CLASS	253		Seat/Door	HKS - Tailgate control																																	
GLC-CLASS	253		Seat/Door	DCM-RR - Door control module rear right																																	
GLC-CLASS	253		Seat/Door	DCM-RL - Door control module rear left																																	
GLC-CLASS	253		Seat/Door	DCM-FR - Door control module front right																																	
GLC-CLASS	253		Seat/Door	DCM-FL - Door control module front left																																	
GLC-CLASS	253		Information	TPAD - Touchpad																																	
GLC-CLASS	253		Information	DAB/SDAR - Digital/Satellite radio																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
GLC-CLASS	253		Information	360' - Camera																																	
GLC-CLASS	253		Information	Sound generator for exhaust system																																	
GLC-CLASS	253		Information	SOUND - Sound system																																	
GLC-CLASS	253		Information	RFK - Backup camera																																	
GLC-CLASS	253		Information	SGR - Radar sensors control unit																																	
GLC-CLASS	253		Information	PTS - Parktronic system																																	
GLC-CLASS	253		Information	NBR-RF - Right front range radar																																	
GLC-CLASS	253		Information	NBR-LF - Left front range radar																																	
GLC-CLASS	253		Information	MFK - Multifunction camera																																	
GLC-CLASS	253		Information	IC - Instrument cluster																																	
GLC-CLASS	253		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLC-CLASS	253		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLC-CLASS	253		Information	Head-up display																																	
GLC-CLASS	253		Information	AUDIO/COMAND																																	
GLC-CLASS	253		Information	SG-MSND - Engine sound																																	
GLC-CLASS	253		Information	ZAN - Audio/COMAND display																																	
GLC-CLASS	253		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLC-CLASS	253		Information	KAB - Camera cover																																	
GLC-CLASS	253		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLC-CLASS	253		Information	AMG Performance Media																																	
GLC-CLASS	253		Air Conditioning	AAC - Automatic air conditioning					V																												
GLE-CLASS	292		Drive	SCR - Selective catalytic reduction									V																								
GLE-CLASS	292		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLE-CLASS	292		Drive	ISM - Intelligent servo module							V																										
GLE-CLASS	292		Drive	DTR - Distronic													V																				
GLE-CLASS	292		Drive	ME/CDI/CNG - Engine control unit				V																									V				
GLE-CLASS	292		Drive	ETC - Electronic transmission control																																	
GLE-CLASS	292		Chassis	TPM - Tire pressure monitor																																	
GLE-CLASS	292		Chassis	FWGW - Chassis gateway																																	
GLE-CLASS	292		Chassis	ABS/ESP - Electronic stability program								V				V			V			V															
GLE-CLASS	292		Chassis	ES - Electrical power steering											V																						
GLE-CLASS	292		Chassis	EFB - Electric parking brake										V																							
GLE-CLASS	292		Chassis	Suspension																																	
GLE-CLASS	292		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLE-CLASS	292		Body	AHE - Trailer recognition																																	
GLE-CLASS	292		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
GLE-CLASS	292		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
GLE-CLASS	292		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
GLE-CLASS	292		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLE-CLASS	292		Body	AB - Airbag																																	
GLE-CLASS	292		Body	Multifunction control unit																																	
GLE-CLASS	292		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLE-CLASS	292		Body	Headlamp-R - Headlamp control unit																																	
GLE-CLASS	292		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLE-CLASS	292		Body	SG-AWF - Collision prevention assist																																	
GLE-CLASS	292		Body	EZS/EIS - Electronic ignition lock																																	
GLE-CLASS	292		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLE-CLASS	292		Information	TPAD - Touchpad																																	
GLE-CLASS	292		Information	DAB/SDAR - Digital/Satellite radio																																	
GLE-CLASS	292		Information	360' - Camera																																	
GLE-CLASS	292		Information	SOUND - Sound system																																	
GLE-CLASS	292		Information	RFK - Backup camera														V		V																	
GLE-CLASS	292		Information	SGR - Radar sensors control unit																																	
GLE-CLASS	292		Information	PTS - Parktronic system																																	
GLE-CLASS	292		Information	MFK - Multifunction camera																				V													
GLE-CLASS	292		Information	NBR-RF - Right front range radar																																	
GLE-CLASS	292		Information	NBR-LF - Left front range radar																																	
GLE-CLASS	292		Information	IC - Instrument cluster																						V								V			
GLE-CLASS	292		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLE-CLASS	292		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLE-CLASS	292		Information	Head-up display																																	
GLE-CLASS	292		Information	AUDIO/COMAND																																	
GLE-CLASS	292		Information	AVE-H - Rear audio video unit																																	
GLE-CLASS	292		Information	DVD player																																	
GLE-CLASS	292		Information	SG-MSND - Engine sound																																	
GLE-CLASS	292		Information	ZAN - Audio/COMAND display																																	
GLE-CLASS	292		Information	D-FOR - Display in right rear passenger																																	
GLE-CLASS	292		Information	D-FOL - Display in left rear passenger																																	
GLE-CLASS	292		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLE-CLASS	292		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLE-CLASS	292		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLE-CLASS	292		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
GLE-CLASS	292		Seat/Door	PSD/MSC - Sliding roof control																																	
GLE-CLASS	292		Seat/Door	HKS - Tailgate control																																	
GLE-CLASS	292		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DCM-RR - Door control module rear right																																	
GLE-CLASS	292		Seat/Door	DCM-RL - Door control module rear left																																	
GLE-CLASS	292		Seat/Door	DCM-FR - Door control module front right																																	
GLE-CLASS	292		Seat/Door	DCM-FL - Door control module front left																																	
GLE-CLASS	292		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLE-CLASS	292		Air Conditioning	HBF - Rear control panel																																	
GLE-CLASS	292		Air Conditioning	AAC - Automatic air conditioning					V	V																											
GL-CLASS	164		Drive	ME/CDI/CNG - Engine control unit				V																				V				V					
GL-CLASS	164		Drive	ETC - Electronic transmission control																																	
GL-CLASS	164		Drive	VG - Transfer case																																	
GL-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
GL-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
GL-CLASS	164		Drive	SCR - Selective catalytic reduction									V																								
GL-CLASS	164		Drive	ISM - Intelligent servo module							V																										
GL-CLASS	164		Drive	HSG - Hybrid control unit																																	
GL-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
GL-CLASS	164		Drive	DTR - Distronic													V																				
GL-CLASS	164		Chassis	ABS/ESP - Electronic stability program			V																						V								
GL-CLASS	164		Chassis	Suspension																																	
GL-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
GL-CLASS	164		Chassis	ES - Electrical power steering																																	
GL-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	164		Body	WSS - Weight sensing system																																	
GL-CLASS	164		Body	UCP - Upper control panel																																	
GL-CLASS	164		Body	System diagnosis																																	
GL-CLASS	164		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GL-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
GL-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
GL-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	164		Body	CGW - Central gateway																																	
GL-CLASS	164		Body	AB - Airbag																																	
GL-CLASS	164		Information	TV - TV tuner																																	
GL-CLASS	164		Information	SOUND - Sound system																																	
GL-CLASS	164		Information	RFK - Backup camera	V	V																															
GL-CLASS	164		Information	PTS - Parktronic system																																	
GL-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	164		Information	NAV - Navigation module																																	
GL-CLASS	164		Information	MIF/UCI - Media interface																																	
GL-CLASS	164		Information	IC - Instrument cluster																						V											V
GL-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GL-CLASS	164		Information	CM - Compass module																																	
GL-CLASS	164		Information	AVE-H - Rear audio video unit																																	
GL-CLASS	164		Information	AUDIO/COMAND																																	
GL-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																													V				
GL-CLASS	164		Information	ASSYST Active Service System																																	
GL-CLASS	164		Information	AGW - Audio gateway																																	
GL-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
GL-CLASS	164		Seat/Door	HS - Seat heater																																	
GL-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
GL-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
GL-CLASS	164		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GL-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
GL-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																						V											
GL-CLASS	166		Drive	SG-EM - Power electronics																																	
GL-CLASS	166		Drive	PTCU - Common powertrain controller																																	
GL-CLASS	166		Drive	ME/CDI/CNG - Engine control unit				V																									V				
GL-CLASS	166		Drive	ETC - Electronic transmission control																																	
GL-CLASS	166		Drive	VG - Transfer case																																	
GL-CLASS	166		Drive	SCR - Selective catalytic reduction									V																								
GL-CLASS	166		Drive	ISM - Intelligent servo module							V																										
GL-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	166		Drive	DTR - Distronic													V																				
GL-CLASS	166		Chassis	ABS/ESP - Electronic stability program								V				V			V			V															
GL-CLASS	166		Chassis	Suspension																																	
GL-CLASS	166		Chassis	ES - Electrical power steering											V																						
GL-CLASS	166		Chassis	EFB - Electric parking brake										V																							
GL-CLASS	166		Chassis	FWGW - Chassis gateway																																	
GL-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
GL-CLASS	166		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GL-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
GL-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
GL-CLASS	166		Body	Multifunction control unit																																	
GL-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GL-CLASS	166		Body	AHE - Trailer recognition																																	
GL-CLASS	166		Body	AB - Airbag																																	
GL-CLASS	166		Information	Sound generator for exhaust system																																	
GL-CLASS	166		Information	Head-up display																																	
GL-CLASS	166		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
GL-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GL-CLASS	166		Information	ZAN - Audio/COMAND display																																	
GL-CLASS	166		Information	TV - TV tuner																																	
GL-CLASS	166		Information	SOUND - Sound system																																	
GL-CLASS	166		Information	SGR - Radar sensors control unit																																	
GL-CLASS	166		Information	360' - Camera																																	
GL-CLASS	166		Information	RFK - Backup camera														V		V																	
GL-CLASS	166		Information	MFK - Multifunction camera																				V													
GL-CLASS	166		Information	PTS - Parktronic system																																	
GL-CLASS	166		Information	NSA - Night View Assist																																	
GL-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	166		Information	NBR-RF - Right front range radar																																	
GL-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	166		Information	NBR-LF - Left front range radar																																	
GL-CLASS	166		Information	NAV - Navigation module																																	
GL-CLASS	166		Information	MIF/UCI - Media interface																																	
GL-CLASS	166		Information	IC - Instrument cluster																						V								V			
GL-CLASS	166		Information	DVD player																																	
GL-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GL-CLASS	166		Information	AUDIO/COMAND																																	
GL-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
GL-CLASS	166		Seat/Door	HKS - Tailgate control																																	
GL-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
GL-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
GL-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
GL-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
GL-CLASS	166		Air Conditioning	HBF - Rear control panel																																		
GL-CLASS	166		Air Conditioning	AAC - Automatic air conditioning					V	V																												
M-CLASS	163		Drive	ME/CDI/CNG - Engine control unit																									V									
M-CLASS	163		Drive	ETC - Electronic transmission control																																		
M-CLASS	163		Drive	ESM - Electronic selector module																																		
M-CLASS	163		Drive	VG - Transfer case																																		
M-CLASS	163		Chassis	ABS/ESP - Electronic stability program			V																							V								
M-CLASS	163		Chassis	VP - Vacuum pump brake booster																																		
M-CLASS	163		Chassis	BAS - Brake assist																																		
M-CLASS	163		Body	Headlamp/Headlamp-L - Headlamp control unit																																		
M-CLASS	163		Body	AB - Airbag																																		
M-CLASS	163		Body	AAM - All activity module																																		
M-CLASS	163		Information	PTS - Parktronic system																																		
M-CLASS	163		Information	IC - Instrument cluster																																		
M-CLASS	163		Information	DTA - Mbrace or TELEAID/GPS Box																																		
M-CLASS	163		Information	AUDIO/COMAND																																		
M-CLASS	163		Air Conditioning	AAC - Automatic air conditioning																																		
M-CLASS	163		Air Conditioning	TSTH/STH - Stationary heater with remote control																					V													
M-CLASS	164		Drive	ME/CDI/CNG - Engine control unit				V																					V				V					
M-CLASS	164		Drive	ETC - Electronic transmission control																																		
M-CLASS	164		Drive	VG - Transfer case																																		
M-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																		
M-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																		
M-CLASS	164		Drive	SCR - Selective catalytic reduction									V																									
M-CLASS	164		Drive	ISM - Intelligent servo module							V																											
M-CLASS	164		Drive	HSG - Hybrid control unit																																		
M-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																		
M-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																		
M-CLASS	164		Drive	DTR - Distronic													V																					
M-CLASS	164		Chassis	ABS/ESP - Electronic stability program			V																							V								
M-CLASS	164		Chassis	Suspension																																		
M-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																		
M-CLASS	164		Chassis	ES - Electrical power steering																																		
M-CLASS	164		Chassis	TPM - Tire pressure monitor																																		
M-CLASS	164		Body	WSS - Weight sensing system																																		
M-CLASS	164		Body	UCP - Upper control panel																																		

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
M-CLASS	164		Body	System diagnosis																																	
M-CLASS	164		Body	SCM [MRM] - Steering column module																																	
M-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
M-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	OCP - Overhead control panel																																	
M-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
M-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	164		Body	CGW - Central gateway																																	
M-CLASS	164		Body	AB - Airbag																																	
M-CLASS	164		Information	TV - TV tuner																																	
M-CLASS	164		Information	SOUND - Sound system																																	
M-CLASS	164		Information	RFK - Backup camera	V	V																															
M-CLASS	164		Information	PTS - Parktronic system																																	
M-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	164		Information	NAV - Navigation module																																	
M-CLASS	164		Information	MIF/UCI - Media interface																																	
M-CLASS	164		Information	IC - Instrument cluster																						V											V
M-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
M-CLASS	164		Information	CM - Compass module																																	
M-CLASS	164		Information	AVE-H - Rear audio video unit																																	
M-CLASS	164		Information	AUDIO/COMAND																																	
M-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																													V				
M-CLASS	164		Information	ASSYST Active Service System																																	
M-CLASS	164		Information	AGW - Audio gateway																																	
M-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
M-CLASS	164		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
M-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
M-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	164		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
M-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																							V										
M-CLASS	166		Drive	SG-EM - Power electronics																																	
M-CLASS	166		Drive	ME/CDI/CNG - Engine control unit				V																									V				
M-CLASS	166		Drive	ETC - Electronic transmission control																																	
M-CLASS	166		Drive	VG - Transfer case																																	
M-CLASS	166		Drive	SCR - Selective catalytic reduction									V																								
M-CLASS	166		Drive	PTCU - Common powertrain controller																																	
M-CLASS	166		Drive	ISM - Intelligent servo module							V																										
M-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	166		Drive	DTR - Distronic													V																				
M-CLASS	166		Chassis	ABS/ESP - Electronic stability program								V				V			V			V															
M-CLASS	166		Chassis	Suspension																																	
M-CLASS	166		Chassis	ES - Electrical power steering											V																						
M-CLASS	166		Chassis	EFB - Electric parking brake										V																							
M-CLASS	166		Chassis	FWGW - Chassis gateway																																	
M-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
M-CLASS	166		Body	SCM [MRM] - Steering column module																																	
M-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
M-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
M-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
M-CLASS	166		Body	Multifunction control unit																																	
M-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
M-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
M-CLASS	166		Body	AHE - Trailer recognition																																	
M-CLASS	166		Body	AB - Airbag																																	
M-CLASS	166		Information	Sound generator for exhaust system																																	
M-CLASS	166		Information	Head-up display																																	
M-CLASS	166		Information	AVE-H - Rear audio video unit																																	
M-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
M-CLASS	166		Information	ZAN - Audio/COMAND display																																	
M-CLASS	166		Information	TV - TV tuner																																	
M-CLASS	166		Information	SOUND - Sound system																																	
M-CLASS	166		Information	SGR - Radar sensors control unit																																	
M-CLASS	166		Information	360' - Camera																																	
M-CLASS	166		Information	RFK - Backup camera														V		V																	
M-CLASS	166		Information	MFK - Multifunction camera																				V													
M-CLASS	166		Information	PTS - Parktronic system																																	
M-CLASS	166		Information	NSA - Night View Assist																																	
M-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	166		Information	NBR-RF - Right front range radar																																	
M-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	166		Information	NBR-LF - Left front range radar																																	
M-CLASS	166		Information	NAV - Navigation module																																	
M-CLASS	166		Information	MIF/UCI - Media interface																																	
M-CLASS	166		Information	IC - Instrument cluster																						V								V			
M-CLASS	166		Information	DVD player																																	
M-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
M-CLASS	166		Information	AUDIO/COMAND																																	
M-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
M-CLASS	166		Seat/Door	HKS - Tailgate control																																	
M-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
M-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
M-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
M-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
M-CLASS	166		Air Conditioning	AAC - Automatic air conditioning					V	V																											
R-CLASS	251		Drive	ME/CDI/CNG - Engine control unit				V																					V				V				
R-CLASS	251		Drive	ETC - Electronic transmission control																																	
R-CLASS	251		Drive	SCR - Selective catalytic reduction									V																								
R-CLASS	251		Drive	ISM - Intelligent servo module							V																										
R-CLASS	251		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
R-CLASS	251		Drive	DTR - Distronic													V																				
R-CLASS	251		Chassis	ABS/ESP - Electronic stability program			V																						V								
R-CLASS	251		Chassis	Suspension																																	
R-CLASS	251		Chassis	ES - Electrical power steering																																	
R-CLASS	251		Chassis	TPM - Tire pressure monitor																																	
R-CLASS	251		Body	WSS - Weight sensing system																																	
R-CLASS	251		Body	UCP - Upper control panel																																	
R-CLASS	251		Body	System diagnosis																																	
R-CLASS	251		Body	SCM [MRM] - Steering column module																																	
R-CLASS	251		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
R-CLASS	251		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
R-CLASS	251		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	OCP - Overhead control panel																																	
R-CLASS	251		Body	LCP/HBF - Lower/Rear control panel																																	
R-CLASS	251		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
R-CLASS	251		Body	Headlamp-R - Headlamp control unit																																	
R-CLASS	251		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
R-CLASS	251		Body	EZS/EIS - Electronic ignition lock																																	
R-CLASS	251		Body	CGW - Central gateway																																	
R-CLASS	251		Body	AB - Airbag																																	
R-CLASS	251		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
R-CLASS	251		Information	SOUND - Sound system																																	
R-CLASS	251		Information	RFK - Backup camera	V	V																															
R-CLASS	251		Information	PTS - Parktronic system																																	
R-CLASS	251		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
R-CLASS	251		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
R-CLASS	251		Information	NAV - Navigation module																																	
R-CLASS	251		Information	MIF/UCI - Media interface																																	
R-CLASS	251		Information	IC - Instrument cluster																						V											V
R-CLASS	251		Information	DTA - Mbrace or TELEAID/GPS Box																																	
R-CLASS	251		Information	D-FOR - Display in right rear passenger																																	
R-CLASS	251		Information	D-FOL - Display in left rear passenger																																	
R-CLASS	251		Information	DAB/SDAR - Digital/Satellite radio																																	
R-CLASS	251		Information	CTEL/TEL - Cellular/Mobile telephone																																	
R-CLASS	251		Information	CM - Compass module																																	
R-CLASS	251		Information	AVE-H - Rear audio video unit																																	
R-CLASS	251		Information	AUDIO/COMAND																																	
R-CLASS	251		Information	ASSYST PLUS - PLUS Active Service System																													V				
R-CLASS	251		Information	ASSYST Active Service System																																	
R-CLASS	251		Information	AGW - Audio gateway																																	
R-CLASS	251		Seat/Door	REDC/RWT - Rear end door control module																																	
R-CLASS	251		Seat/Door	HS - Seat heater																																	
R-CLASS	251		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
R-CLASS	251		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
R-CLASS	251		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
R-CLASS	251		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DCM-FR - Door control module front right																																	
R-CLASS	251		Seat/Door	DCM-FL - Door control module front left																																	
R-CLASS	251		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
R-CLASS	251		Air Conditioning	AAC - Automatic air conditioning																							V										
CLA-CLASS	117		Drive	VG - Transfer case																																	
CLA-CLASS	117		Drive	ME/CDI/CNG - Engine control unit				V																									V				
CLA-CLASS	117		Drive	ETC - Electronic transmission control																																	
CLA-CLASS	117		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLA-CLASS	117		Drive	DTR - Distronic													V																				
CLA-CLASS	117		Drive	DSI - Direct select interface																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
CLA-CLASS	117		Drive	PTCU - Common powertrain controller																																	
CLA-CLASS	117		Chassis	ABS/ESP - Electronic stability program								V										V															
CLA-CLASS	117		Chassis	ES - Electrical power steering											V																						
CLA-CLASS	117		Chassis	EFB - Electric parking brake										V																							
CLA-CLASS	117		Chassis	TPM - Tire pressure monitor																																	
CLA-CLASS	117		Body	SG-AWF - Collision prevention assist																																	
CLA-CLASS	117		Body	SCM [MRM] - Steering column module																																	
CLA-CLASS	117		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLA-CLASS	117		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
CLA-CLASS	117		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
CLA-CLASS	117		Body	Multifunction control unit																																	
CLA-CLASS	117		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLA-CLASS	117		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLA-CLASS	117		Body	EZS/EIS - Electronic ignition lock																																	
CLA-CLASS	117		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CLA-CLASS	117		Body	AHE - Trailer recognition																																	
CLA-CLASS	117		Body	AB - Airbag																																	
CLA-CLASS	117		Information	Head-up display																																	
CLA-CLASS	117		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLA-CLASS	117		Information	KAB - Camera cover																																	
CLA-CLASS	117		Information	ZAN - Audio/COMAND display																																	
CLA-CLASS	117		Information	TV - TV tuner																																	
CLA-CLASS	117		Information	SOUND - Sound system																																	
CLA-CLASS	117		Information	RFK - Backup camera														V		V																	
CLA-CLASS	117		Information	MFK - Multifunction camera																				V													
CLA-CLASS	117		Information	PTS - Parktronic system																																	
CLA-CLASS	117		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLA-CLASS	117		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLA-CLASS	117		Information	NAV - Navigation module																																	
CLA-CLASS	117		Information	MIF/UCI - Media interface																																	
CLA-CLASS	117		Information	IC - Instrument cluster																						V								V			
CLA-CLASS	117		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLA-CLASS	117		Information	DAB/SDAR - Digital/Satellite radio																																	
CLA-CLASS	117		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLA-CLASS	117		Information	AUDIO/COMAND																																	
CLA-CLASS	117		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
CLA-CLASS	117		Seat/Door	PSD/MSC - Sliding roof control																																	
CLA-CLASS	117		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLA-CLASS	117		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLA-CLASS	117		Seat/Door	DCM-FR - Door control module front right																																	
CLA-CLASS	117		Seat/Door	DCM-FL - Door control module front left																																	
CLA-CLASS	117		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLA-CLASS	117		Air Conditioning	AAC - Automatic air conditioning					V	V																											
CLK-CLASS	208		Drive	ME/CDI/CNG - Engine control unit																								V									
CLK-CLASS	208		Drive	ETC - Electronic transmission control																																	
CLK-CLASS	208		Drive	ESM - Electronic selector module																																	
CLK-CLASS	208		Chassis	PSE - Pneumatic system equipment																																	
CLK-CLASS	208		Chassis	ABS/ESP - Electronic stability program																																	
CLK-CLASS	208		Chassis	VP - Vacuum pump brake booster																																	
CLK-CLASS	208		Chassis	BAS - Brake assist																																	
CLK-CLASS	208		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	208		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	208		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	208		Body	OCP - Overhead control panel																																	
CLK-CLASS	208		Body	AB - Airbag																																	
CLK-CLASS	208		Information	TV - TV tuner																																	
CLK-CLASS	208		Information	PTS - Parktronic system																																	
CLK-CLASS	208		Information	NAV - Navigation module																																	
CLK-CLASS	208		Information	IC - Instrument cluster																						V											
CLK-CLASS	208		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	208		Information	AUDIO/COMAND																																	
CLK-CLASS	208		Information	APS - Auto pilot system																																	
CLK-CLASS	208		Air Conditioning	TSTH/STH - Stationary heater with remote control																					V												
CLK-CLASS	208		Air Conditioning	AAC - Automatic air conditioning																																	
CLK-CLASS	208		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	208		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	208		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	208		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Drive	ME/CDI/CNG - Engine control unit																								V				V					
CLK-CLASS	209		Drive	ETC - Electronic transmission control																																	
CLK-CLASS	209		Drive	ESM - Electronic selector module																																	
CLK-CLASS	209		Drive	DTR - Distronic																																V	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
CLK-CLASS	209		Chassis	ABS/ESP - Electronic stability program			V																							V							
CLK-CLASS	209		Chassis	TPM - Tire pressure monitor																																	
CLK-CLASS	209		Body	WSS - Weight sensing system																																	
CLK-CLASS	209		Body	UCP - Upper control panel																																	
CLK-CLASS	209		Body	SCM [MRM] - Steering column module																																V	
CLK-CLASS	209		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLK-CLASS	209		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	209		Body	RCM - Rear control module																																	
CLK-CLASS	209		Body	OCP - Overhead control panel																																	
CLK-CLASS	209		Body	Multifunction control unit																																	
CLK-CLASS	209		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	209		Body	Headlamp-R - Headlamp control unit																																	
CLK-CLASS	209		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLK-CLASS	209		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	209		Body	BNS/BMS - Battery sensor																																	
CLK-CLASS	209		Body	AHE - Trailer recognition																																	
CLK-CLASS	209		Body	AB - Airbag																																	
CLK-CLASS	209		Information	TV - TV tuner																																	
CLK-CLASS	209		Information	PTS - Parktronic system																																	
CLK-CLASS	209		Information	NAV - Navigation module																																	
CLK-CLASS	209		Information	IC - Instrument cluster																						V											V
CLK-CLASS	209		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	209		Information	AUDIO/COMAND																																	
CLK-CLASS	209		Information	AGW - Audio gateway																																	
CLK-CLASS	209		Seat/Door	RVC/VDS - Convertible roof control																																	
CLK-CLASS	209		Seat/Door	REDC/RWT - Rear end door control module																																	
CLK-CLASS	209		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	209		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	209		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	209		Air Conditioning	TSTH/STH - Stationary heater with remote control																								V									
CLK-CLASS	209		Air Conditioning	AAC - Automatic air conditioning																							V										
CLS-CLASS	219		Drive	ME/CDI/CNG - Engine control unit																									V				V				
CLS-CLASS	219		Drive	ETC - Electronic transmission control																																	
CLS-CLASS	219		Drive	ESM - Electronic selector module																																	
CLS-CLASS	219		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
CLS-CLASS	219		Drive	DTR - Distronic																																	
CLS-CLASS	219		Chassis	ABS/ESP - Electronic stability program			V																							V								
CLS-CLASS	219		Chassis	Suspension																																	
CLS-CLASS	219		Chassis	SBC - Sensotronic Brake Control																																	
CLS-CLASS	219		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	219		Body	WSS - Weight sensing system																																	
CLS-CLASS	219		Body	UCP - Upper control panel																																	
CLS-CLASS	219		Body	System diagnosis																																	
CLS-CLASS	219		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	219		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	219		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CLS-CLASS	219		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLS-CLASS	219		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	OCP - Overhead control panel																																	
CLS-CLASS	219		Body	LCP/HBF - Lower/Rear control panel																																	
CLS-CLASS	219		Body	LAE [LAA] - Loading floor automatically extendable																																	
CLS-CLASS	219		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	219		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	219		Body	CGW - Central gateway																																	
CLS-CLASS	219		Body	BNS/BMS - Battery sensor																																	
CLS-CLASS	219		Body	AB - Airbag																																	
CLS-CLASS	219		Information	TV - TV tuner																																	
CLS-CLASS	219		Information	SOUND - Sound system																																	
CLS-CLASS	219		Information	PTS - Parktronic system																																	
CLS-CLASS	219		Information	MIF/UCI - Media interface																																	
CLS-CLASS	219		Information	IC - Instrument cluster																						V											V
CLS-CLASS	219		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	219		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	219		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	219		Information	AUDIO/COMAND																																	
CLS-CLASS	219		Information	ASSYST PLUS - PLUS Active Service System																													V				
CLS-CLASS	219		Information	ASSYST Active Service System																																	
CLS-CLASS	219		Information	AGW - Audio gateway																																	
CLS-CLASS	219		Seat/Door	REDC/RWT - Rear end door control module																																	
CLS-CLASS	219		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
CLS-CLASS	219		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	219		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	219		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	219		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	219		Seat/Door	DCM-RL - Door control module rear left																																	
CLS-CLASS	219		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	219		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	219		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	219		Air Conditioning	AAC - Automatic air conditioning																							V										
CLS-CLASS	218		Drive	ME/CDI/CNG - Engine control unit				V																									V				
CLS-CLASS	218		Drive	ETC - Electronic transmission control																																	
CLS-CLASS	218		Drive	ESM - Electronic selector module																																	
CLS-CLASS	218		Drive	SCR - Selective catalytic reduction									V																								
CLS-CLASS	218		Drive	ISM - Intelligent servo module							V																										
CLS-CLASS	218		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLS-CLASS	218		Drive	DTR - Distronic													V																				
CLS-CLASS	218		Drive	DSI - Direct select interface																																	
CLS-CLASS	218		Drive	AMG DRIVE UNIT																																	
CLS-CLASS	218		Chassis	ABS/ESP - Electronic stability program								V										V															
CLS-CLASS	218		Chassis	Suspension																																	
CLS-CLASS	218		Chassis	ES - Electrical power steering											V																						
CLS-CLASS	218		Chassis	FWGW - Chassis gateway																																	
CLS-CLASS	218		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	218		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
CLS-CLASS	218		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
CLS-CLASS	218		Body	WSS - Weight sensing system																																	
CLS-CLASS	218		Body	SG-AWF - Collision prevention assist																																	
CLS-CLASS	218		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	218		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	218		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLS-CLASS	218		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
CLS-CLASS	218		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
CLS-CLASS	218		Body	OCP - Overhead control panel																																	
CLS-CLASS	218		Body	Multifunction control unit																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
CLS-CLASS	218		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLS-CLASS	218		Body	HSW/LRH - Steering wheel heater																																	
CLS-CLASS	218		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
CLS-CLASS	218		Body	Headlamp-R - Headlamp control unit																																	
CLS-CLASS	218		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	218		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	218		Body	CGW - Central gateway																																	
CLS-CLASS	218		Body	AHE - Trailer recognition																																	
CLS-CLASS	218		Body	AB - Airbag																																	
CLS-CLASS	218		Information	360' - Camera																																	
CLS-CLASS	218		Information	AVE-H - Rear audio video unit																																	
CLS-CLASS	218		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLS-CLASS	218		Information	ZAN - Audio/COMAND display																																	
CLS-CLASS	218		Information	TV - TV tuner																																	
CLS-CLASS	218		Information	SOUND - Sound system																																	
CLS-CLASS	218		Information	SGR - Radar sensors control unit																																	
CLS-CLASS	218		Information	MFK - Multifunction camera																				V													
CLS-CLASS	218		Information	RFK - Backup camera	V													V		V			V														
CLS-CLASS	218		Information	PTS - Parktronic system																																	
CLS-CLASS	218		Information	NSA - Night View Assist																																	
CLS-CLASS	218		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLS-CLASS	218		Information	NBR-RF - Right front range radar																																	
CLS-CLASS	218		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLS-CLASS	218		Information	NBR-LF - Left front range radar																																	
CLS-CLASS	218		Information	NAV - Navigation module																																	
CLS-CLASS	218		Information	MIF/UCI - Media interface																																	
CLS-CLASS	218		Information	ICI - InCar Internet																																	
CLS-CLASS	218		Information	IC - Instrument cluster																						V								V			
CLS-CLASS	218		Information	DVD player																																	
CLS-CLASS	218		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	218		Information	D-FOR - Display in right rear passenger																																	
CLS-CLASS	218		Information	D-FOL - Display in left rear passenger																																	
CLS-CLASS	218		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	218		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	218		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLS-CLASS	218		Information	AUDIO/COMAND																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
CLS-CLASS	218		Seat/Door	PSD/MSC - Sliding roof control																																	
CLS-CLASS	218		Seat/Door	HKS - Tailgate control																																	
CLS-CLASS	218		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	218		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	218		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	218		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	218		Seat/Door	DCM-RL - Door control module rear left																																	
CLS-CLASS	218		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	218		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	218		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	218		Air Conditioning	AAC - Automatic air conditioning					V	V																											
CL-CLASS	215		Drive	ME/CDI/CNG - Engine control unit																								V									
CL-CLASS	215		Drive	ETC - Electronic transmission control																																	
CL-CLASS	215		Drive	ESM - Electronic selector module																																	
CL-CLASS	215		Drive	DTR - Distronic																																V	
CL-CLASS	215		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	215		Chassis	Suspension																	V																
CL-CLASS	215		Chassis	PSE - Pneumatic system equipment																																	
CL-CLASS	215		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	215		Body	UCP - Upper control panel																																	
CL-CLASS	215		Body	System diagnosis																																	
CL-CLASS	215		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	215		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	215		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CL-CLASS	215		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	215		Body	RCM - Rear control module																																	
CL-CLASS	215		Body	OCP - Overhead control panel																																	
CL-CLASS	215		Body	Multifunction control unit																																	
CL-CLASS	215		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	215		Body	HSW/LRH - Steering wheel heater																																	
CL-CLASS	215		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	215		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	215		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	215		Body	CGW - Central gateway																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
CL-CLASS	215		Body	AHE - Trailer recognition																																	
CL-CLASS	215		Body	AB - Airbag																																	
CL-CLASS	215		Information	TV - TV tuner																																	
CL-CLASS	215		Information	PTS - Parktronic system																																	
CL-CLASS	215		Information	NAV - Navigation module																																	
CL-CLASS	215		Information	IC - Instrument cluster																						V											
CL-CLASS	215		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	215		Information	AUDIO/COMAND																																	
CL-CLASS	215		Information	AGW - Audio gateway																																	
CL-CLASS	215		Seat/Door	OSB-FR - Multicontour backrest front right																																	
CL-CLASS	215		Seat/Door	OSB-FL - Multicontour backrest front left																																	
CL-CLASS	215		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	215		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	215		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	215		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	215		Air Conditioning	TSTH/STH - Stationary heater with remote control																					V												
CL-CLASS	215		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
CL-CLASS	215		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	216		Drive	ME/CDI/CNG - Engine control unit				V																									V				
CL-CLASS	216		Drive	ETC - Electronic transmission control																																	
CL-CLASS	216		Drive	ISM - Intelligent servo module							V																										
CL-CLASS	216		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	216		Drive	DTR - Distronic													V																				
CL-CLASS	216		Chassis	ABS/ESP - Electronic stability program								V			V			V			V																
CL-CLASS	216		Chassis	Suspension																																	
CL-CLASS	216		Chassis	ES - Electrical power steering																																	
CL-CLASS	216		Chassis	EFB - Electric parking brake																																	
CL-CLASS	216		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	216		Body	WSS - Weight sensing system																																	
CL-CLASS	216		Body	UCP - Upper control panel																																	
CL-CLASS	216		Body	System diagnosis																																	
CL-CLASS	216		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	216		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	216		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	216		Body	RCM - Rear control module																																	
CL-CLASS	216		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
CL-CLASS	216		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	216		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	216		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	216		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	216		Body	CGW - Central gateway																																	
CL-CLASS	216		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	216		Body	AHE - Trailer recognition																																	
CL-CLASS	216		Body	AB - Airbag																																	
CL-CLASS	216		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	216		Information	VCS - Voice control																																	
CL-CLASS	216		Information	TV - TV tuner																																	
CL-CLASS	216		Information	Tuner - Standard tuner																																	
CL-CLASS	216		Information	SGR - Radar sensors control unit																																	
CL-CLASS	216		Information	MFK - Multifunction camera																				V													
CL-CLASS	216		Information	RFK - Backup camera	V																		V														
CL-CLASS	216		Information	PTS - Parktronic system																																	
CL-CLASS	216		Information	NSA - Night View Assist																																	
CL-CLASS	216		Information	NBR-LF - Left front range radar																																	
CL-CLASS	216		Information	NAV - Navigation module																																	
CL-CLASS	216		Information	MIF/UCI - Media interface																																	
CL-CLASS	216		Information	ICI - InCar Internet																																	
CL-CLASS	216		Information	IC - Instrument cluster																																	
CL-CLASS	216		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	216		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	216		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	216		Information	AUDIO/COMAND																																	
CL-CLASS	216		Information	ASSYST PLUS - PLUS Active Service System																																	
CL-CLASS	216		Information	ASSYST Active Service System																																	
CL-CLASS	216		Seat/Door	TLC/GTO - Garage door opener																																	
CL-CLASS	216		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	216		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	216		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	216		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	216		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
CL-CLASS	216		Seat/Door	DCM-FL - Door control module front left																																		
CL-CLASS	216		Air Conditioning	TSTH/STH - Stationary heater with remote control																																		
CL-CLASS	216		Air Conditioning	AAC - Automatic air conditioning																																		
CL-CLASS	217		Drive	SCR - Selective catalytic reduction									V																									
CL-CLASS	217		Drive	SG-EM - Power electronics																																		
CL-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																		
CL-CLASS	217		Drive	DTR - Distronic																																		
CL-CLASS	217		Drive	ISM - Intelligent servo module							V																											
CL-CLASS	217		Drive	ME/CDI/CNG - Engine control unit				V																									V					
CL-CLASS	217		Drive	ETC - Electronic transmission control																																		
CL-CLASS	217		Drive	PTCU - Common powertrain controller																																		
CL-CLASS	217		Chassis	TPM - Tire pressure monitor																																		
CL-CLASS	217		Chassis	ABS/ESP - Electronic stability program																																		
CL-CLASS	217		Chassis	ES - Electrical power steering																																		
CL-CLASS	217		Chassis	Suspension																																		
CL-CLASS	217		Chassis	EFB - Electric parking brake										V																								
CL-CLASS	217		Information	TPAD - Touchpad																																		
CL-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																		
CL-CLASS	217		Information	360' - Camera																																		
CL-CLASS	217		Information	SOUND - Sound system																																		
CL-CLASS	217		Information	RFK - Backup camera																																		
CL-CLASS	217		Information	SGR - Radar sensors control unit																																		
CL-CLASS	217		Information	PTS - Parktronic system																																		
CL-CLASS	217		Information	NSA - Night View Assist																																		
CL-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																		
CL-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																		
CL-CLASS	217		Information	NBR-RF - Right front range radar																																		
CL-CLASS	217		Information	NBR-LF - Left front range radar																																		
CL-CLASS	217		Information	MFK - Multifunction camera																																		
CL-CLASS	217		Information	Head-up display																																		
CL-CLASS	217		Information	AUDIO/COMAND																																		
CL-CLASS	217		Information	ZAN - Audio/COMAND display																																		
CL-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																		
CL-CLASS	217		Information	KAB - Camera cover																																		
CL-CLASS	217		Information	IC - Instrument cluster																																		
CL-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																		

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
CL-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CL-CLASS	217		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	AB - Airbag																																	
CL-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
CL-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	217		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																														V			
CL-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	217		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
CL-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
CL-CLASS	217		Air Conditioning	AAC - Automatic air conditioning					V																												
SLK-CLASS	170		Drive	ME/CDI/CNG - Engine control unit																								V									
SLK-CLASS	170		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	170		Drive	ESM - Electronic selector module																																	
SLK-CLASS	170		Chassis	ABS/ESP - Electronic stability program			V																						V								
SLK-CLASS	170		Chassis	VP - Vacuum pump brake booster																																	
SLK-CLASS	170		Chassis	BAS - Brake assist																																	
SLK-CLASS	170		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	170		Body	AB - Airbag																																	
SLK-CLASS	170		Information	IC - Instrument cluster																																	
SLK-CLASS	170		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	170		Information	AUDIO/COMAND																																	
SLK-CLASS	170		Air Conditioning	TSTH/STH - Stationary heater with remote control																					V												

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
SLK-CLASS	170		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	171		Drive	ME/CDI/CNG - Engine control unit																									V				V				
SLK-CLASS	171		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	171		Drive	ESM - Electronic selector module																																	
SLK-CLASS	171		Chassis	ABS/ESP - Electronic stability program			V																							V							
SLK-CLASS	171		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	171		Body	WSS - Weight sensing system																																	
SLK-CLASS	171		Body	UCP - Upper control panel																																	
SLK-CLASS	171		Body	System diagnosis																																	
SLK-CLASS	171		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	171		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	171		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLK-CLASS	171		Body	OCP - Overhead control panel																																	
SLK-CLASS	171		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	171		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	171		Body	CGW - Central gateway																																	
SLK-CLASS	171		Body	AB - Airbag																																	
SLK-CLASS	171		Information	TV - TV tuner																																	
SLK-CLASS	171		Information	SOUND - Sound system																																	
SLK-CLASS	171		Information	PTS - Parktronic system																																	
SLK-CLASS	171		Information	MIF/UCI - Media interface																																	
SLK-CLASS	171		Information	IC - Instrument cluster																						V											V
SLK-CLASS	171		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	171		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	171		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SLK-CLASS	171		Information	AUDIO/COMAND																																	
SLK-CLASS	171		Information	ASSYST PLUS - PLUS Active Service System																													V				
SLK-CLASS	171		Information	ASSYST Active Service System																																	
SLK-CLASS	171		Information	AGW - Audio gateway																																	
SLK-CLASS	171		Seat/Door	RVC/VDS - Convertible roof control																																	
SLK-CLASS	171		Seat/Door	HS - Seat heater																																	
SLK-CLASS	171		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	171		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	171		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	171		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	171		Air Conditioning	AAC - Automatic air conditioning																							V										

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
SLK-CLASS	172		Drive	ME/CDI/CNG - Engine control unit				V																									V				
SLK-CLASS	172		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	172		Drive	ESM - Electronic selector module																																	
SLK-CLASS	172		Drive	DTR - Distronic													V																				
SLK-CLASS	172		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLK-CLASS	172		Chassis	ABS/ESP - Electronic stability program								V										V															
SLK-CLASS	172		Chassis	Suspension																																	
SLK-CLASS	172		Chassis	ES - Electrical power steering																																	
SLK-CLASS	172		Chassis	EFB - Electric parking brake										V																							
SLK-CLASS	172		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	172		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	172		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	172		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLK-CLASS	172		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
SLK-CLASS	172		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
SLK-CLASS	172		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	172		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLK-CLASS	172		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	172		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	172		Body	CGW - Central gateway																																	
SLK-CLASS	172		Body	AB - Airbag																																	
SLK-CLASS	172		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SLK-CLASS	172		Information	ZAN - Audio/COMAND display																																	
SLK-CLASS	172		Information	TV - TV tuner																																	
SLK-CLASS	172		Information	SOUND - Sound system																																	
SLK-CLASS	172		Information	SGR - Radar sensors control unit																																	
SLK-CLASS	172		Information	MFK - Multifunction camera																				V													
SLK-CLASS	172		Information	PTS - Parktronic system																																	
SLK-CLASS	172		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLK-CLASS	172		Information	NBR-RF - Right front range radar																																	
SLK-CLASS	172		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLK-CLASS	172		Information	NBR-LF - Left front range radar																																	
SLK-CLASS	172		Information	NAV - Navigation module																																	
SLK-CLASS	172		Information	MIF/UCI - Media interface																																	
SLK-CLASS	172		Information	IC - Instrument cluster																						V								V			
SLK-CLASS	172		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
SLK-CLASS	172		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	172		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLK-CLASS	172		Information	AUDIO/COMAND																																	
SLK-CLASS	172		Seat/Door	RVC/VDS - Convertible roof control																																	
SLK-CLASS	172		Seat/Door	PSD/MSC - Sliding roof control																																	
SLK-CLASS	172		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	172		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	172		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	172		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	172		Air Conditioning	AAC - Automatic air conditioning					V	V																											
SL-CLASS	129		Drive	ME/CDI/CNG - Engine control unit																																	
SL-CLASS	129		Drive	ETC - Electronic transmission control																																	
SL-CLASS	129		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	129		Chassis	BAS - Brake assist																																	
SL-CLASS	129		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	129		Body	AB - Airbag																																	
SL-CLASS	129		Information	NAV - Navigation module																																	
SL-CLASS	129		Information	IC - Instrument cluster																						V											
SL-CLASS	129		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	129		Information	AUDIO/COMAND																																	
SL-CLASS	129		Information	APS - Auto pilot system																																	
SL-CLASS	129		Air Conditioning	TSTH/STH - Stationary heater with remote control																					V												
SL-CLASS	129		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	230		Drive	ME/CDI/CNG - Engine control unit																								V				V					
SL-CLASS	230		Drive	ETC - Electronic transmission control																																	
SL-CLASS	230		Drive	ESM - Electronic selector module																																	
SL-CLASS	230		Drive	DTR - Distronic																																V	
SL-CLASS	230		Drive	AMG DRIVE UNIT																																	
SL-CLASS	230		Chassis	ABS/ESP - Electronic stability program			V																						V								
SL-CLASS	230		Chassis	Suspension																	V																
SL-CLASS	230		Chassis	SBC - Sensotronic Brake Control																																	
SL-CLASS	230		Chassis	PSE - Pneumatic system equipment																																	
SL-CLASS	230		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	230		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	230		Body	WSS - Weight sensing system																																	
SL-CLASS	230		Body	System diagnosis																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
SL-CLASS	230		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	230		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	230		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SL-CLASS	230		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	230		Body	OCP - Overhead control panel																																	
SL-CLASS	230		Body	LCP/HBF - Lower/Rear control panel																																	
SL-CLASS	230		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	230		Body	HSW/LRH - Steering wheel heater																																	
SL-CLASS	230		Body	Headlamp-R - Headlamp control unit																																	
SL-CLASS	230		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	230		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	230		Body	CGW - Central gateway																																	
SL-CLASS	230		Body	BNS/BMS - Battery sensor																																	
SL-CLASS	230		Body	AB - Airbag																																	
SL-CLASS	230		Information	TV - TV tuner																																	
SL-CLASS	230		Information	SOUND - Sound system																																	
SL-CLASS	230		Information	PTS - Parktronic system																																	
SL-CLASS	230		Information	MIF/UCI - Media interface																																	
SL-CLASS	230		Information	IC - Instrument cluster																						V											
SL-CLASS	230		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	230		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	230		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SL-CLASS	230		Information	AUDIO/COMAND																																	
SL-CLASS	230		Information	AGW - Audio gateway																																	
SL-CLASS	230		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	230		Seat/Door	OSB-FR - Multicontour backrest front right																																	
SL-CLASS	230		Seat/Door	OSB-FL - Multicontour backrest front left																																	
SL-CLASS	230		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	230		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	230		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	230		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	230		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	230		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	231		Drive	ME/CDI/CNG - Engine control unit				V																									V				
SL-CLASS	231		Drive	ETC - Electronic transmission control																																	
SL-CLASS	231		Drive	ISM - Intelligent servo module							V																										

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
SL-CLASS	231		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SL-CLASS	231		Drive	DTR - Distronic													V																				
SL-CLASS	231		Drive	DSI - Direct select interface																																	
SL-CLASS	231		Drive	AMG DRIVE UNIT																																	
SL-CLASS	231		Chassis	ABS/ESP - Electronic stability program								V										V															
SL-CLASS	231		Chassis	Suspension																																	
SL-CLASS	231		Chassis	ES - Electrical power steering											V																						
SL-CLASS	231		Chassis	EFB - Electric parking brake										V																							
SL-CLASS	231		Chassis	FWGW - Chassis gateway																																	
SL-CLASS	231		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	231		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	231		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	231		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	231		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
SL-CLASS	231		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
SL-CLASS	231		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	231		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	231		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	231		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	231		Body	CGW - Central gateway																																	
SL-CLASS	231		Body	AB - Airbag																																	
SL-CLASS	231		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SL-CLASS	231		Information	ZAN - Audio/COMAND display																																	
SL-CLASS	231		Information	TV - TV tuner																																	
SL-CLASS	231		Information	SOUND - Sound system																																	
SL-CLASS	231		Information	SGR - Radar sensors control unit																																	
SL-CLASS	231		Information	RFK - Backup camera														V		V																	
SL-CLASS	231		Information	MFK - Multifunction camera																				V													
SL-CLASS	231		Information	PTS - Parktronic system																																	
SL-CLASS	231		Information	NSA - Night View Assist																																	
SL-CLASS	231		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SL-CLASS	231		Information	NBR-RF - Right front range radar																																	
SL-CLASS	231		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SL-CLASS	231		Information	NBR-LF - Left front range radar																																	
SL-CLASS	231		Information	MIF/UCI - Media interface																																	
SL-CLASS	231		Information	IC - Instrument cluster																						V								V			

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
SL-CLASS	231		Information	DTA - Mbrace or TELEAID/GPS Box																																		
SL-CLASS	231		Information	DAB/SDAR - Digital/Satellite radio																																		
SL-CLASS	231		Information	COU [ZBE] - Audio/COMAND operating unit																																		
SL-CLASS	231		Information	AUDIO/COMAND																																		
SL-CLASS	231		Information	AMG Performance Media																																		
SL-CLASS	231		Seat/Door	RVC/VDS - Convertible roof control																																		
SL-CLASS	231		Seat/Door	PSD/MSC - Sliding roof control																																		
SL-CLASS	231		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																		
SL-CLASS	231		Seat/Door	ESA Driver - Electric seat adjustment Driver																																		
SL-CLASS	231		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																		
SL-CLASS	231		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																		
SL-CLASS	231		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																		
SL-CLASS	231		Seat/Door	DCM-FR - Door control module front right																																		
SL-CLASS	231		Seat/Door	DCM-FL - Door control module front left																																		
SL-CLASS	231		Air Conditioning	AAC - Automatic air conditioning					V	V																												
SLS-CLASS	197		Drive	PTCU - Common powertrain controller																																		
SLS-CLASS	197		Drive	ME/CDI/CNG - Engine control unit																													V					
SLS-CLASS	197		Drive	ETC - Electronic transmission control																																		
SLS-CLASS	197		Drive	ISM - Intelligent servo module							V																											
SLS-CLASS	197		Drive	FSCU/FSCU-L - Control unit Fuel pump																																		
SLS-CLASS	197		Drive	DSI - Direct select interface																																		
SLS-CLASS	197		Drive	AMG DRIVE UNIT																																		
SLS-CLASS	197		Chassis	ABS/ESP - Electronic stability program								V										V																
SLS-CLASS	197		Chassis	Suspension																																		
SLS-CLASS	197		Chassis	ES - Electrical power steering																																		
SLS-CLASS	197		Chassis	EFB - Electric parking brake										V																								
SLS-CLASS	197		Chassis	TPM - Tire pressure monitor																																		
SLS-CLASS	197		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V												
SLS-CLASS	197		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V												
SLS-CLASS	197		Body	CSHV - Crash sensor/high-voltage battery																																		
SLS-CLASS	197		Body	BNS/BMS - Battery sensor				V					V																				V					
SLS-CLASS	197		Body	WSS - Weight sensing system																																		
SLS-CLASS	197		Body	SCM [MRM] - Steering column module																																		
SLS-CLASS	197		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																		
SLS-CLASS	197		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																		
SLS-CLASS	197		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																		

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
SLS-CLASS	197		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLS-CLASS	197		Body	EZS/EIS - Electronic ignition lock																																	
SLS-CLASS	197		Body	CGW - Central gateway																																	
SLS-CLASS	197		Body	AB - Airbag																																	
SLS-CLASS	197		Information	MFK - Multifunction camera																				V													
SLS-CLASS	197		Information	SGR - Radar sensors control unit																																	
SLS-CLASS	197		Information	ZAN - Audio/COMAND display																																	
SLS-CLASS	197		Information	SOUND - Sound system																																	
SLS-CLASS	197		Information	PTS - Parktronic system																																	
SLS-CLASS	197		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLS-CLASS	197		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLS-CLASS	197		Information	MIF/UCI - Media interface																																	
SLS-CLASS	197		Information	IC - Instrument cluster																						V								V			
SLS-CLASS	197		Information	DTA - Mbrace or TELEAID/GPS Box													V																				
SLS-CLASS	197		Information	DAB/SDAR - Digital/Satellite radio																																	
SLS-CLASS	197		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLS-CLASS	197		Information	AUDIO/COMAND																																	
SLS-CLASS	197		Information	AMG Performance Media																																	
SLS-CLASS	197		Seat/Door	RVC/VDS - Convertible roof control																																	
SLS-CLASS	197		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLS-CLASS	197		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLS-CLASS	197		Seat/Door	DCM-FR - Door control module front right																																	
SLS-CLASS	197		Seat/Door	DCM-FL - Door control module front left																																	
SLS-CLASS	197		Air Conditioning	AAC - Automatic air conditioning					V	V																											
AMG GT	190		Drive	DTR - Distronic													V																				
AMG GT	190		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
AMG GT	190		Drive	DSI - Direct select interface																																	
AMG GT	190		Drive	AMG DRIVE UNIT																																	
AMG GT	190		Drive	PTCU - Common powertrain controller																																	
AMG GT	190		Drive	ME/CDI/CNG - Engine control unit				V																									V				
AMG GT	190		Drive	ETC - Electronic transmission control																																	
AMG GT	190		Chassis	TPM - Tire pressure monitor																																	
AMG GT	190		Chassis	Suspension																																	
AMG GT	190		Chassis	ABS/ESP - Electronic stability program								V										V															
AMG GT	190		Chassis	EFB - Electric parking brake										V																							
AMG GT	190		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
AMG GT	190		Information	DAB/SDAR - Digital/Satellite radio																																	
AMG GT	190		Information	SOUND - Sound system																																	
AMG GT	190		Information	RFK - Backup camera																																	
AMG GT	190		Information	PTS - Parktronic system																																	
AMG GT	190		Information	MFK - Multifunction camera																				V													
AMG GT	190		Information	IC - Instrument cluster																																	
AMG GT	190		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
AMG GT	190		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
AMG GT	190		Information	AUDIO/COMAND																																	
AMG GT	190		Information	ZAN - Audio/COMAND display																																	
AMG GT	190		Information	COU [ZBE] - Audio/COMAND operating unit																																	
AMG GT	190		Information	DTA - Mbrace or TELEAID/GPS Box																																	
AMG GT	190		Information	AMG Performance Media																																	
AMG GT	190		Body	SCM [MRM] - Steering column module																																	
AMG GT	190		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
AMG GT	190		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
AMG GT	190		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
AMG GT	190		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
AMG GT	190		Body	AB - Airbag																																	
AMG GT	190		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
AMG GT	190		Body	Headlamp-R - Headlamp control unit																																	
AMG GT	190		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
AMG GT	190		Body	SG-AWF - Collision prevention assist																																	
AMG GT	190		Body	EZS/EIS - Electronic ignition lock																																	
AMG GT	190		Body	CGW - Central gateway																																	
AMG GT	190		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
AMG GT	190		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
AMG GT	190		Seat/Door	DCM-FR - Door control module front right																																	
AMG GT	190		Seat/Door	DCM-FL - Door control module front left																																	
AMG GT	190		Air Conditioning	AAC - Automatic air conditioning				V	V																												
SLR-CLASS	199		Drive	ME/CDI/CNG - Engine control unit																								V									
SLR-CLASS	199		Drive	ETC - Electronic transmission control																																	
SLR-CLASS	199		Drive	ESM - Electronic selector module																																	
SLR-CLASS	199		Chassis	ABS/ESP - Electronic stability program																																	
SLR-CLASS	199		Chassis	SBC - Sensotronic Brake Control																																	
SLR-CLASS	199		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
SLR-CLASS	199		Body	WSS - Weight sensing system																																	
SLR-CLASS	199		Body	SCM [MRM] - Steering column module																																	
SLR-CLASS	199		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLR-CLASS	199		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SLR-CLASS	199		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLR-CLASS	199		Body	OCP - Overhead control panel																																	
SLR-CLASS	199		Body	LCP/HBF - Lower/Rear control panel																																	
SLR-CLASS	199		Body	Headlamp-R - Headlamp control unit																																	
SLR-CLASS	199		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLR-CLASS	199		Body	EZS/EIS - Electronic ignition lock																																	
SLR-CLASS	199		Body	CGW - Central gateway																																	
SLR-CLASS	199		Body	BNS/BMS - Battery sensor																																	
SLR-CLASS	199		Body	AB - Airbag																																	
SLR-CLASS	199		Information	IC - Instrument cluster																						V											
SLR-CLASS	199		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLR-CLASS	199		Information	AUDIO/COMAND																																	
SLR-CLASS	199		Seat/Door	DCM-FR - Door control module front right																																	
SLR-CLASS	199		Seat/Door	DCM-FL - Door control module front left																																	
SLR-CLASS	199		Air Conditioning	AAC - Automatic air conditioning																																	
MAYBACH	240		Drive	ME/CDI/CNG - Engine control unit																								V				V					
MAYBACH	240		Drive	ETC - Electronic transmission control																																	
MAYBACH	240		Drive	ESM - Electronic selector module																																	
MAYBACH	240		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
MAYBACH	240		Drive	DTR - Distronic																																V	
MAYBACH	240		Chassis	ABS/ESP - Electronic stability program																																	
MAYBACH	240		Chassis	Suspension																																	
MAYBACH	240		Chassis	SBC - Sensotronic Brake Control																																	
MAYBACH	240		Chassis	TPM - Tire pressure monitor																																	
MAYBACH	240		Body	WSS - Weight sensing system																																	
MAYBACH	240		Body	System diagnosis																																	
MAYBACH	240		Body	SCM [MRM] - Steering column module																																V	
MAYBACH	240		Body	HSW/LRH - Steering wheel heater																																	
MAYBACH	240		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
MAYBACH	240		Body	AB - Airbag																																	
MAYBACH	240		Information	TV - TV tuner																																	
MAYBACH	240		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
MAYBACH	240		Information	DTA - Mbrace or TELEAID/GPS Box																																	
MAYBACH	240		Information	AGW - Audio gateway																																	
MAYBACH	240		Seat/Door	REDC/RWT - Rear end door control module																																	
MAYBACH	240		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All_Model(BETA)	16P Connector		Drive	SG-EM - Power electronics																																	
All_Model(BETA)	16P Connector		Drive	HFPM - Haptic accelerator pedal module																																	
All_Model(BETA)	16P Connector		Drive	ME/CDI/CNG - Engine control unit				V																				V				V					
All_Model(BETA)	16P Connector		Drive	ETC - Electronic transmission control																																	
All_Model(BETA)	16P Connector		Drive	ESM - Electronic selector module																																	
All_Model(BETA)	16P Connector		Drive	VG - Transfer case																																	
All_Model(BETA)	16P Connector		Drive	VECU - Power monitoring control unit																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-B - Electric motor control unit B																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-A - Electric motor control unit A																																	
All_Model(BETA)	16P Connector		Drive	SCR - Selective catalytic reduction									V																								
All_Model(BETA)	16P Connector		Drive	PTCU - Common powertrain controller																																	
All_Model(BETA)	16P Connector		Drive	Natural gas control unit																																	
All_Model(BETA)	16P Connector		Drive	ISM - Intelligent servo module							V																										
All_Model(BETA)	16P Connector		Drive	Hydrogen tank control unit																																	
All_Model(BETA)	16P Connector		Drive	HSG - Hybrid control unit																																	
All_Model(BETA)	16P Connector		Drive	High-temperature coolant pump control unit																																	
All_Model(BETA)	16P Connector		Drive	Fuel cell control unit																																	
All_Model(BETA)	16P Connector		Drive	FSCU-R - Control unit fuel pump																																	
All_Model(BETA)	16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
All_Model(BETA)	16P Connector		Drive	EMPI - Electronic Motor Pump Inverter																																	
All_Model(BETA)	16P Connector		Drive	Electric drive control unit																																	
All_Model(BETA)	16P Connector		Drive	DTR - Distronic													V																			V	
All_Model(BETA)	16P Connector		Drive	DSI - Direct select interface																																	
All_Model(BETA)	16P Connector		Drive	Compressed Natural Gas Control Module																																	
All_Model(BETA)	16P Connector		Drive	CC - Cruise control																																	
All_Model(BETA)	16P Connector		Drive	BSA - Belt-driven starter/alternator																																	
All_Model(BETA)	16P Connector		Drive	AMG DRIVE UNIT																																	
All_Model(BETA)	16P Connector		Drive	ACS - Automatic clutch system																																	
All_Model(BETA)	16P Connector		Chassis	ABS/ESP - Electronic stability program			V					V			V			V			V								V								
All_Model(BETA)	16P Connector		Chassis	Suspension																V																	
All_Model(BETA)	16P Connector		Chassis	SBC - Sensotronic Brake Control																																	
All_Model(BETA)	16P Connector		Chassis	PSE - Pneumatic system equipment																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
All_Model(BETA)	16P Connector		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
All_Model(BETA)	16P Connector		Chassis	HAQ - Interwheel differential lock at rear axle																																	
All_Model(BETA)	16P Connector		Chassis	FWGW - Chassis gateway																																	
All_Model(BETA)	16P Connector		Chassis	ES - Electrical power steering											V																						
All_Model(BETA)	16P Connector		Chassis	EFB - Electric parking brake										V																							
All_Model(BETA)	16P Connector		Chassis	BAS - Brake assist																																	
All_Model(BETA)	16P Connector		Chassis	VP - Vacuum pump brake booster																																	
All_Model(BETA)	16P Connector		Chassis	TPM - Tire pressure monitor																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
All_Model(BETA)	16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
All_Model(BETA)	16P Connector		Body	CSHV - Crash sensor/high-voltage battery																																	
All_Model(BETA)	16P Connector		Body	WSS - Weight sensing system																																	
All_Model(BETA)	16P Connector		Body	UCP - Upper control panel																																	
All_Model(BETA)	16P Connector		Body	System diagnosis																																	
All_Model(BETA)	16P Connector		Body	SG-DDW - DC/DC converter control unit																																	
All_Model(BETA)	16P Connector		Body	SG-AWF - Collision prevention assist																																	
All_Model(BETA)	16P Connector		Body	SCM [MRM] - Steering column module																																V	
All_Model(BETA)	16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
All_Model(BETA)	16P Connector		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
All_Model(BETA)	16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																														V			
All_Model(BETA)	16P Connector		Body	RevETR-RF - Right front reversible emergency tensioning retractor																						V											
All_Model(BETA)	16P Connector		Body	RevETR-LF - Left front reversible emergency tensioning retractor																						V											
All_Model(BETA)	16P Connector		Body	RCM - Rear control module																																	
All_Model(BETA)	16P Connector		Body	OCP - Overhead control panel																																	
All_Model(BETA)	16P Connector		Body	Multifunction control unit																																	
All_Model(BETA)	16P Connector		Body	LCP/HBF - Lower/Rear control panel																																	
All_Model(BETA)	16P Connector		Body	LAE [LAA] - Loading floor automatically extendable																																	
All_Model(BETA)	16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
All_Model(BETA)	16P Connector		Body	HSW/LRH - Steering wheel heater																																	
All_Model(BETA)	16P Connector		Body	Headlamp-R - Headlamp control unit																																	
All_Model(BETA)	16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
All_Model(BETA)	16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
All_Model(BETA)	16P Connector		Body	CGW - Central gateway																																	
All_Model(BETA)	16P Connector		Body	BNS/BMS - Battery sensor																																	
All_Model(BETA)	16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
All_Model(BETA)	16P Connector		Body	AHE - Trailer recognition																																	
All_Model(BETA)	16P Connector		Body	AB - Airbag																																	
All_Model(BETA)	16P Connector		Body	AAM - All activity module																																	
All_Model(BETA)	16P Connector		Information	TPAD - Touchpad																																	
All_Model(BETA)	16P Connector		Information	Head-up display																																	
All_Model(BETA)	16P Connector		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
All_Model(BETA)	16P Connector		Information	KAB - Camera cover																																	
All_Model(BETA)	16P Connector		Information	ZAN - Audio/COMAND display																																	
All_Model(BETA)	16P Connector		Information	VCS - Voice control																																	
All_Model(BETA)	16P Connector		Information	TV - TV tuner																																	
All_Model(BETA)	16P Connector		Information	Tuner - Standard tuner																																	
All_Model(BETA)	16P Connector		Information	Sound generator for exhaust system																																	
All_Model(BETA)	16P Connector		Information	SOUND - Sound system																																	
All_Model(BETA)	16P Connector		Information	SGR - Radar sensors control unit																																	
All_Model(BETA)	16P Connector		Information	360' - Camera																																	
All_Model(BETA)	16P Connector		Information	MFK - Multifunction camera																				V													
All_Model(BETA)	16P Connector		Information	RFK - Backup camera	V	V												V		V			V														
All_Model(BETA)	16P Connector		Information	PTS - Parktronic system																																	
All_Model(BETA)	16P Connector		Information	NSA - Night View Assist																																	
All_Model(BETA)	16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-RF - Right front range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LF - Left front range radar																																	
All_Model(BETA)	16P Connector		Information	NAV - Navigation module																																	
All_Model(BETA)	16P Connector		Information	MIF/UCI - Media interface																																	
All_Model(BETA)	16P Connector		Information	ICI - InCar Internet																																	
All_Model(BETA)	16P Connector		Information	IC - Instrument cluster																						V								V			V
All_Model(BETA)	16P Connector		Information	DVD player																																	
All_Model(BETA)	16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
All_Model(BETA)	16P Connector		Information	D-FOR - Display in right rear passenger																																	
All_Model(BETA)	16P Connector		Information	D-FOL - Display in left rear passenger																																	
All_Model(BETA)	16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
All_Model(BETA)	16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
All_Model(BETA)	16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
All_Model(BETA)	16P Connector		Information	CM - Compass module																																	
All_Model(BETA)	16P Connector		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset
All Model(BETA)	16P Connector		Information	AUDIO/COMAND																																		
All Model(BETA)	16P Connector		Information	ASSYST PLUS - PLUS Active Service System																														V				
All Model(BETA)	16P Connector		Information	ASSYST Active Service System																																		
All Model(BETA)	16P Connector		Information	APS - Auto pilot system																																		
All Model(BETA)	16P Connector		Information	AMG Performance Media																																		
All Model(BETA)	16P Connector		Information	AGW - Audio gateway																																		
All Model(BETA)	16P Connector		Seat/Door	Right rear ESE - Right electrical seat adjustment																																		
All Model(BETA)	16P Connector		Seat/Door	Left rear ESE - Left electrical seat adjustment																																		
All Model(BETA)	16P Connector		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																		
All Model(BETA)	16P Connector		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																		
All Model(BETA)	16P Connector		Seat/Door	TSG-MR - Right center door control unit																																		
All Model(BETA)	16P Connector		Seat/Door	TSG-ML - Left center door control unit																																		
All Model(BETA)	16P Connector		Seat/Door	TLC/GTO - Garage door opener																																		
All Model(BETA)	16P Connector		Seat/Door	RVC/VDS - Convertible roof control																																		
All Model(BETA)	16P Connector		Seat/Door	REDC/RWT - Rear end door control module																																		
All Model(BETA)	16P Connector		Seat/Door	PSD/MSC - Sliding roof control																																		
All Model(BETA)	16P Connector		Seat/Door	OSB-R - Multicontour backrest rear																																		
All Model(BETA)	16P Connector		Seat/Door	OSB-FR - Multicontour backrest front right																																		
All Model(BETA)	16P Connector		Seat/Door	OSB-FL - Multicontour backrest front left																																		
All Model(BETA)	16P Connector		Seat/Door	MKL-HR - Rear right multicontour backrest																																		
All Model(BETA)	16P Connector		Seat/Door	MKL-HL - Rear left multicontour backrest																																		
All Model(BETA)	16P Connector		Seat/Door	HS - Seat heater																																		
All Model(BETA)	16P Connector		Seat/Door	HKS - Tailgate control																																		
All Model(BETA)	16P Connector		Seat/Door	ESA-R - Electric seat adjustment rear																																		
All Model(BETA)	16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																		
All Model(BETA)	16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																		
All Model(BETA)	16P Connector		Seat/Door	ERA - Electric fold down backrest system																																		
All Model(BETA)	16P Connector		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																		
All Model(BETA)	16P Connector		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																		
All Model(BETA)	16P Connector		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																		
All Model(BETA)	16P Connector		Seat/Door	DCM-RR - Door control module rear right																																		
All Model(BETA)	16P Connector		Seat/Door	DCM-RL - Door control module rear left																																		
All Model(BETA)	16P Connector		Seat/Door	DCM-FR - Door control module front right																																		
All Model(BETA)	16P Connector		Seat/Door	DCM-FL - Door control module front left																																		
All Model(BETA)	16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																							V											
All Model(BETA)	16P Connector		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																		
All Model(BETA)	16P Connector		Air Conditioning	HBF - Rear control panel																																		
All Model(BETA)	16P Connector		Air Conditioning	HB - Heater booster																					V													
All Model(BETA)	16P Connector		Air Conditioning	EKMK - Electric refrigerant compressor																																		
All Model(BETA)	16P Connector		Air Conditioning	AAC - Automatic air conditioning					V	V																V												

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
A-CLASS	68		Drive	ME/CDI/CNG - Engine control unit																			V														
A-CLASS	68		Drive	ETC - Electronic transmission control																																	
A-CLASS	68		Drive	ESM - Electronic selector module																																	
A-CLASS	68		Drive	ACS - Automatic clutch system																																	
A-CLASS	68		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Body	LCP/HBF - Lower/Rear control panel																																	
A-CLASS	168		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	168		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	168		Body	AB - Airbag																																	
A-CLASS	168		Information	PTS - Parktronic system																																	
A-CLASS	168		Information	IC - Instrument cluster																V																	
A-CLASS	168		Information	AUDIO/COMAND																																	
A-CLASS	168		Information	APS - Auto pilot system																																	
A-CLASS	168		Seat/Door	DCM-RR - Door control module rear right																													V				
A-CLASS	168		Seat/Door	DCM-RL - Door control module rear left																													V		V	V	
A-CLASS	168		Seat/Door	DCM-FR - Door control module front right																														V			
A-CLASS	168		Seat/Door	DCM-FL - Door control module front left																														V			
A-CLASS	168		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	168		Air Conditioning	HB - Heater booster																																	
A-CLASS	168		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	169		Drive	ME/CDI/CNG - Engine control unit				V	V	V	V	V	V		V	V	V	V																			
A-CLASS	169		Drive	ETC - Electronic transmission control																																	
A-CLASS	169		Drive	ESM - Electronic selector module																																	
A-CLASS	169		Drive	BSA - Belt-driven starter/alternator																																	
A-CLASS	169		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	169		Chassis	ES - Electrical power steering																																	
A-CLASS	169		Body	SCM [MRM] - Steering column module																																	
A-CLASS	169		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
A-CLASS	169		Body	OCP - Overhead control panel																																	
A-CLASS	169		Body	Multifunction control unit																																	
A-CLASS	169		Body	Headlamp-R - Headlamp control unit																																	
A-CLASS	169		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
A-CLASS	169		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	169		Body	CGW - Central gateway																																	
A-CLASS	169		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
A-CLASS	169		Body	AHE - Trailer recognition																																	
A-CLASS	169		Body	AB - Airbag																																	
A-CLASS	169		Information	SOUND - Sound system																																	
A-CLASS	169		Information	PTS - Parktronic system																																	
A-CLASS	169		Information	MIF/UCI - Media interface																																	
A-CLASS	169		Information	IC - Instrument cluster		V														V																	
A-CLASS	169		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	169		Information	CTEL/TEL - Cellular/Mobile telephone																																	
A-CLASS	169		Information	AUDIO/COMAND																																	
A-CLASS	169		Information	ASSYST PLUS - PLUS Active Service System																																	
A-CLASS	169		Information	ASSYST Active Service System																V																	
A-CLASS	169		Information	AGW - Audio gateway																																	
A-CLASS	169		Seat/Door	DCM-RR - Door control module rear right																												V					
A-CLASS	169		Seat/Door	DCM-RL - Door control module rear left																												V					
A-CLASS	169		Seat/Door	DCM-FR - Door control module front right																												V	V				
A-CLASS	169		Seat/Door	DCM-FL - Door control module front left																												V	V				
A-CLASS	169		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	176		Drive	VG - Transfer case																																	
A-CLASS	176		Drive	ME/CDI/CNG - Engine control unit																																	
A-CLASS	176		Drive	ETC - Electronic transmission control																																	
A-CLASS	176		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
A-CLASS	176		Drive	DTR - Distronic																																	
A-CLASS	176		Drive	DSI - Direct select interface																																	
A-CLASS	176		Drive	PTCU - Common powertrain controller																																	
A-CLASS	176		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	176		Chassis	ES - Electrical power steering																																	
A-CLASS	176		Chassis	EFB - Electric parking brake																																	
A-CLASS	176		Chassis	TPM - Tire pressure monitor																																	
A-CLASS	176		Body	SG-AWF - Collision prevention assist																																	
A-CLASS	176		Body	SCM [MRM] - Steering column module																																	
A-CLASS	176		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
A-CLASS	176		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	Multifunction control unit																																	
A-CLASS	176		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	176		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
A-CLASS	176		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	176		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	176		Body	AHE - Trailer recognition																																	
A-CLASS	176		Body	AB - Airbag																																	
A-CLASS	176		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
A-CLASS	176		Information	ZAN - Audio/COMAND display																																	
A-CLASS	176		Information	TV - TV tuner																																	
A-CLASS	176		Information	SOUND - Sound system																																	
A-CLASS	176		Information	RFK - Backup camera																																	
A-CLASS	176		Information	MFK - Multifunction camera																																	
A-CLASS	176		Information	PTS - Parktronic system																																	
A-CLASS	176		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
A-CLASS	176		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
A-CLASS	176		Information	NAV - Navigation module																																	
A-CLASS	176		Information	MIF/UCI - Media interface																																	
A-CLASS	176		Information	IC - Instrument cluster																																	
A-CLASS	176		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
A-CLASS	176		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	176		Information	COU [ZBE] - Audio/COMAND operating unit																																	
A-CLASS	176		Information	AUDIO/COMAND																																	
A-CLASS	176		Seat/Door	PSD/MSC - Sliding roof control																																	
A-CLASS	176		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
A-CLASS	176		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
A-CLASS	176		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
A-CLASS	176		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
A-CLASS	176		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	176		Air Conditioning	AAC - Automatic air conditioning																																	
B-CLASS	245		Drive	ME/CDI/CNG - Engine control unit				V	V	V	V	V	V		V	V	V	V																			
B-CLASS	245		Drive	ETC - Electronic transmission control																																	
B-CLASS	245		Drive	ESM - Electronic selector module																																	
B-CLASS	245		Drive	Hydrogen tank control unit																																	
B-CLASS	245		Drive	High-temperature coolant pump control unit																																	
B-CLASS	245		Drive	Fuel cell control unit																																	
B-CLASS	245		Drive	Electric drive control unit																																	
B-CLASS	245		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	245		Drive	BSA - Belt-driven starter/alternator																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
B-CLASS	245		Drive	VECU - Power monitoring control unit																																	
B-CLASS	245		Chassis	ABS/ESP - Electronic stability program																																	
B-CLASS	245		Chassis	ES - Electrical power steering																																	
B-CLASS	245		Chassis	VP - Vacuum pump brake booster																																	
B-CLASS	245		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	245		Body	WSS - Weight sensing system																																	
B-CLASS	245		Body	SG-DDW - DC/DC converter control unit																																	
B-CLASS	245		Body	SCM [MRM] - Steering column module																																	
B-CLASS	245		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
B-CLASS	245		Body	OCP - Overhead control panel																																	
B-CLASS	245		Body	Multifunction control unit																																	
B-CLASS	245		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	245		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	245		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	245		Body	CGW - Central gateway																																	
B-CLASS	245		Body	BNS/BMS - Battery sensor																																	
B-CLASS	245		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	245		Body	AHE - Trailer recognition																																	
B-CLASS	245		Body	AB - Airbag																																	
B-CLASS	245		Information	SOUND - Sound system																																	
B-CLASS	245		Information	PTS - Parktronic system																																	
B-CLASS	245		Information	NAV - Navigation module																																	
B-CLASS	245		Information	MIF/UCI - Media interface																																	
B-CLASS	245		Information	IC - Instrument cluster		V														V																	
B-CLASS	245		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	245		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	245		Information	CTEL/TEL - Cellular/Mobile telephone																																	
B-CLASS	245		Information	CM - Compass module																																	
B-CLASS	245		Information	AUDIO/COMAND																																	
B-CLASS	245		Information	ASSYST PLUS - PLUS Active Service System																																	
B-CLASS	245		Information	ASSYST Active Service System																V																	
B-CLASS	245		Information	AGW - Audio gateway																																	
B-CLASS	245		Seat/Door	DCM-RR - Door control module rear right																												V					
B-CLASS	245		Seat/Door	DCM-RL - Door control module rear left																												V					
B-CLASS	245		Seat/Door	DCM-FR - Door control module front right																												V	V				
B-CLASS	245		Seat/Door	DCM-FL - Door control module front left																												V	V				

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
B-CLASS	245		Air Conditioning	EKMK - Electric refrigerant compressor																																	
B-CLASS	245		Air Conditioning	AAC - Automatic air conditioning																																	
B-CLASS	246		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	246		Drive	VG - Transfer case																																	
B-CLASS	246		Drive	ME/CDI/CNG - Engine control unit																																	
B-CLASS	246		Drive	ETC - Electronic transmission control																																	
B-CLASS	246		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
B-CLASS	246		Drive	DTR - Distronic																																	
B-CLASS	246		Drive	PTCU - Common powertrain controller																																	
B-CLASS	246		Chassis	ABS/ESP - Electronic stability program																																	
B-CLASS	246		Chassis	ES - Electrical power steering																																	
B-CLASS	246		Chassis	EFB - Electric parking brake																																	
B-CLASS	246		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	246		Body	BNS/BMS - Battery sensor																																	
B-CLASS	246		Body	SG-AWF - Collision prevention assist																																	
B-CLASS	246		Body	SCM [MRM] - Steering column module																																	
B-CLASS	246		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
B-CLASS	246		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	Multifunction control unit																																	
B-CLASS	246		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
B-CLASS	246		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	246		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	246		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	246		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	246		Body	AHE - Trailer recognition																																	
B-CLASS	246		Body	AB - Airbag																																	
B-CLASS	246		Information	Sound generator for exhaust system																																	
B-CLASS	246		Information	Head-up display																																	
B-CLASS	246		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
B-CLASS	246		Information	ZAN - Audio/COMAND display																																	
B-CLASS	246		Information	TV - TV tuner																																	
B-CLASS	246		Information	SOUND - Sound system																																	
B-CLASS	246		Information	RFK - Backup camera																																	
B-CLASS	246		Information	MFK - Multifunction camera																																	
B-CLASS	246		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
B-CLASS	246		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
B-CLASS	246		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
B-CLASS	246		Information	NAV - Navigation module																																	
B-CLASS	246		Information	MIF/UCI - Media interface																																	
B-CLASS	246		Information	IC - Instrument cluster																																	
B-CLASS	246		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
B-CLASS	246		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	246		Information	COU [ZBE] - Audio/COMAND operating unit																																	
B-CLASS	246		Information	AUDIO/COMAND																																	
B-CLASS	246		Seat/Door	PSD/MSC - Sliding roof control																																	
B-CLASS	246		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
B-CLASS	246		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
B-CLASS	246		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
B-CLASS	246		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
B-CLASS	246		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
B-CLASS	246		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	202		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V								V															
C-CLASS	202		Drive	ETC - Electronic transmission control																																	
C-CLASS	202		Drive	ESM - Electronic selector module																																	
C-CLASS	202		Chassis	PSE - Pneumatic system equipment																																	
C-CLASS	202		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	202		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	202		Chassis	BAS - Brake assist																																	
C-CLASS	202		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	202		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	202		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	202		Body	OCP - Overhead control panel																																	
C-CLASS	202		Body	AB - Airbag																																	
C-CLASS	202		Information	PTS - Parktronic system																																	
C-CLASS	202		Information	NAV - Navigation module																																	
C-CLASS	202		Information	IC - Instrument cluster															V																		
C-CLASS	202		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	202		Information	AUDIO/COMAND																																	
C-CLASS	202		Information	APS - Auto pilot system																																	
C-CLASS	202		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	202		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
C-CLASS	202		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	202		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	202		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	202		Air Conditioning	HB - Heater booster																																	
C-CLASS	202		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	203		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V				V															
C-CLASS	203		Drive	ETC - Electronic transmission control																																	
C-CLASS	203		Drive	ESM - Electronic selector module																																	
C-CLASS	203		Drive	DTR - Distronic																																	
C-CLASS	203		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	203		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	203		Chassis	BAS - Brake assist																																	
C-CLASS	203		Body	WSS - Weight sensing system																																	
C-CLASS	203		Body	UCP - Upper control panel																																	
C-CLASS	203		Body	System diagnosis																																	
C-CLASS	203		Body	SCM [MRM] - Steering column module																																	
C-CLASS	203		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	203		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	203		Body	OCP - Overhead control panel																																	
C-CLASS	203		Body	Multifunction control unit																																	
C-CLASS	203		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	203		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	203		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	203		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	203		Body	CGW - Central gateway																																	
C-CLASS	203		Body	AHE - Trailer recognition																																	
C-CLASS	203		Body	AB - Airbag																																	
C-CLASS	203		Information	TV - TV tuner																																	
C-CLASS	203		Information	SOUND - Sound system																																	
C-CLASS	203		Information	PTS - Parktronic system																																	
C-CLASS	203		Information	NAV - Navigation module																																	
C-CLASS	203		Information	MIF/UCI - Media interface																																	
C-CLASS	203		Information	IC - Instrument cluster		V														V																	
C-CLASS	203		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	203		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	203		Information	CTEL/TEL - Cellular/Mobile telephone																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
C-CLASS	203		Information	AUDIO/COMAND																																	
C-CLASS	203		Information	AGW - Audio gateway																																	
C-CLASS	203		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	203		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	203		Seat/Door	DCM-RR - Door control module rear right																												V					
C-CLASS	203		Seat/Door	DCM-RL - Door control module rear left																												V					
C-CLASS	203		Seat/Door	DCM-FR - Door control module front right																												V	V				
C-CLASS	203		Seat/Door	DCM-FL - Door control module front left																												V	V				
C-CLASS	203		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	203		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	204		Drive	ME/CDI/CNG - Engine control unit				V	V	V	V	V	V		V	V	V	V																			
C-CLASS	204		Drive	ETC - Electronic transmission control																																	
C-CLASS	204		Drive	ESM - Electronic selector module																																	
C-CLASS	204		Drive	SCR - Selective catalytic reduction																																	
C-CLASS	204		Drive	ISM - Intelligent servo module																																	
C-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
C-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	204		Drive	DTR - Distronic																																	
C-CLASS	204		Drive	AMG DRIVE UNIT																																	
C-CLASS	204		Drive	PTCU - Common powertrain controller																																	
C-CLASS	204		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	204		Chassis	Suspension																																	
C-CLASS	204		Chassis	ES - Electrical power steering																																	
C-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	204		Body	WSS - Weight sensing system																																	
C-CLASS	204		Body	SCM [MRM] - Steering column module																																	
C-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
C-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	OCP - Overhead control panel																																	
C-CLASS	204		Body	Multifunction control unit																																	
C-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	204		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
C-CLASS	204		Body	CGW - Central gateway																																	
C-CLASS	204		Body	AHE - Trailer recognition																																	
C-CLASS	204		Body	AB - Airbag																																	
C-CLASS	204		Information	Head-up display																																	
C-CLASS	204		Information	AVE-H - Rear audio video unit																																	
C-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
C-CLASS	204		Information	ZAN - Audio/COMAND display																																	
C-CLASS	204		Information	TV - TV tuner																																	
C-CLASS	204		Information	Sound generator for exhaust system																																	
C-CLASS	204		Information	SOUND - Sound system																																	
C-CLASS	204		Information	SGR - Radar sensors control unit																																	
C-CLASS	204		Information	360' - Camera																																	
C-CLASS	204		Information	MFK - Multifunction camera																																	
C-CLASS	204		Information	RFK - Backup camera																																	
C-CLASS	204		Information	PTS - Parktronic system																																	
C-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	204		Information	NBR-RF - Right front range radar																																	
C-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	204		Information	NBR-LF - Left front range radar																																	
C-CLASS	204		Information	NAV - Navigation module																																	
C-CLASS	204		Information	MIF/UCI - Media interface																																	
C-CLASS	204		Information	ICI - InCar Internet																																	
C-CLASS	204		Information	IC - Instrument cluster																																	
C-CLASS	204		Information	DVD player																																	
C-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
C-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
C-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
C-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
C-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	204		Information	AUDIO/COMAND																																	
C-CLASS	204		Information	AMG Performance Media																																	
C-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	204		Seat/Door	HKS - Tailgate control																																	
C-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
C-CLASS	204		Seat/Door	DCM-RR - Door control module rear right		V																			V						V		V				
C-CLASS	204		Seat/Door	DCM-RL - Door control module rear left		V																			V		V						V				
C-CLASS	204		Seat/Door	DCM-FR - Door control module front right		V																			V					V			V				
C-CLASS	204		Seat/Door	DCM-FL - Door control module front left		V																			V	V							V				
C-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	204		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	205		Drive	SCR - Selective catalytic reduction																																	
C-CLASS	205		Drive	SG-EM - Power electronics																																	
C-CLASS	205		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	205		Drive	HFPM - Haptic accelerator pedal module																																	
C-CLASS	205		Drive	DTR - Distronic																																	
C-CLASS	205		Drive	ISM - Intelligent servo module																																	
C-CLASS	205		Drive	ME/CDI/CNG - Engine control unit																																	
C-CLASS	205		Drive	ETC - Electronic transmission control																																	
C-CLASS	205		Drive	PTCU - Common powertrain controller																																	
C-CLASS	205		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	205		Chassis	Suspension																																	
C-CLASS	205		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	205		Chassis	ES - Electrical power steering																																	
C-CLASS	205		Chassis	EFB - Electric parking brake																																	
C-CLASS	205		Information	TPAD - Touchpad		V																															
C-CLASS	205		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	205		Information	360' - Camera																																	
C-CLASS	205		Information	Sound generator for exhaust system																																	
C-CLASS	205		Information	SOUND - Sound system																																	
C-CLASS	205		Information	RFK - Backup camera																																	
C-CLASS	205		Information	SGR - Radar sensors control unit																																	
C-CLASS	205		Information	PTS - Parktronic system																																	
C-CLASS	205		Information	NBR-RF - Right front range radar																																	
C-CLASS	205		Information	NBR-LF - Left front range radar																																	
C-CLASS	205		Information	MFK - Multifunction camera																																	
C-CLASS	205		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	205		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	205		Information	Head-up display																																	
C-CLASS	205		Information	AUDIO/COMAND																																	
C-CLASS	205		Information	ZAN - Audio/COMAND display																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
C-CLASS	205		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	205		Information	KAB - Camera cover																																	
C-CLASS	205		Information	IC - Instrument cluster																																	
C-CLASS	205		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
C-CLASS	205		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
C-CLASS	205		Body	AHE - Trailer recognition																																	
C-CLASS	205		Body	SCM [MRM] - Steering column module																																	
C-CLASS	205		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	AB - Airbag																																	
C-CLASS	205		Body	Multifunction control unit																																	
C-CLASS	205		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	205		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	205		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	205		Body	SG-AWF - Collision prevention assist																																	
C-CLASS	205		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	205		Body	BNS/BMS - Battery sensor																																	
C-CLASS	205		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	205		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	205		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	205		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	205		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	205		Seat/Door	HKS - Tailgate control																																	
C-CLASS	205		Seat/Door	DCM-RR - Door control module rear right																			V														
C-CLASS	205		Seat/Door	DCM-RL - Door control module rear left																			V														
C-CLASS	205		Seat/Door	DCM-FR - Door control module front right																			V														
C-CLASS	205		Seat/Door	DCM-FL - Door control module front left																			V														
C-CLASS	205		Seat/Door	RVC/VDS - Convertible roof control																																	
C-CLASS	205		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	124		Drive	PMS/HFM/LH																																	
E-CLASS	124		Drive	ETC - Electronic transmission control																																	
E-CLASS	124		Drive	ISC - Idle speed control																																	
E-CLASS	124		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	124		Body	AB - Airbag																																	
E-CLASS	210		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V								V															
E-CLASS	210		Drive	ETC - Electronic transmission control																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
E-CLASS	210		Drive	ESM - Electronic selector module																																	
E-CLASS	210		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	210		Chassis	VP - Vacuum pump brake booster																																	
E-CLASS	210		Chassis	PSE - Pneumatic system equipment																																	
E-CLASS	210		Chassis	BAS - Brake assist																																	
E-CLASS	210		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	210		Body	OCP - Overhead control panel																																	
E-CLASS	210		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	210		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	210		Body	AB - Airbag																																	
E-CLASS	210		Information	TV - TV tuner																																	
E-CLASS	210		Information	PTS - Parktronic system																																	
E-CLASS	210		Information	NAV - Navigation module																																	
E-CLASS	210		Information	IC - Instrument cluster		V													V	V																	
E-CLASS	210		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	210		Information	AUDIO/COMAND																																	
E-CLASS	210		Information	APS - Auto pilot system																																	
E-CLASS	210		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	210		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	210		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	210		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	210		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	210		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	210		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	210		Air Conditioning	HB - Heater booster																																	
E-CLASS	210		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	211		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V				V															
E-CLASS	211		Drive	ETC - Electronic transmission control																																	
E-CLASS	211		Drive	ESM - Electronic selector module																																	
E-CLASS	211		Drive	Natural gas control unit																																	
E-CLASS	211		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	211		Drive	DTR - Distronic																																	
E-CLASS	211		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	211		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	211		Chassis	Suspension																																	
E-CLASS	211		Chassis	SBC - Sensotronic Brake Control																		V															

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
E-CLASS	211		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	211		Body	WSS - Weight sensing system																																	
E-CLASS	211		Body	UCP - Upper control panel																																	
E-CLASS	211		Body	System diagnosis																																	
E-CLASS	211		Body	SCM [MRM] - Steering column module																																	
E-CLASS	211		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	211		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
E-CLASS	211		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	211		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	OCP - Overhead control panel																																	
E-CLASS	211		Body	Multifunction control unit																																	
E-CLASS	211		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	211		Body	LAE [LAA] - Loading floor automatically extendable																																	
E-CLASS	211		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	211		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	211		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	211		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	211		Body	CGW - Central gateway																																	
E-CLASS	211		Body	BNS/BMS - Battery sensor																																	
E-CLASS	211		Body	AHE - Trailer recognition																																	
E-CLASS	211		Body	AB - Airbag																																	
E-CLASS	211		Information	TV - TV tuner																																	
E-CLASS	211		Information	SOUND - Sound system																																	
E-CLASS	211		Information	PTS - Parktronic system																																	
E-CLASS	211		Information	MIF/UCI - Media interface																																	
E-CLASS	211		Information	IC - Instrument cluster		V														V																	
E-CLASS	211		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	211		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	211		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	211		Information	AUDIO/COMAND																																	
E-CLASS	211		Information	ASSYST PLUS - PLUS Active Service System																																	
E-CLASS	211		Information	ASSYST Active Service System																V																	
E-CLASS	211		Information	AGW - Audio gateway																																	
E-CLASS	211		Seat/Door	REDC/RWT - Rear end door control module																							V				V						
E-CLASS	211		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
E-CLASS	211		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	211		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	211		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	211		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DCM-RR - Door control module rear right																												V					
E-CLASS	211		Seat/Door	DCM-RL - Door control module rear left																												V					
E-CLASS	211		Seat/Door	DCM-FR - Door control module front right																												V	V				
E-CLASS	211		Seat/Door	DCM-FL - Door control module front left																												V	V				
E-CLASS	211		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	211		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	207		Drive	SG-EM - Power electronics																																	
E-CLASS	207		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	207		Drive	ME/CDI/CNG - Engine control unit				V	V	V	V	V	V		V	V	V	V																			
E-CLASS	207		Drive	ETC - Electronic transmission control																																	
E-CLASS	207		Drive	ESM - Electronic selector module																																	
E-CLASS	207		Drive	ISM - Intelligent servo module																																	
E-CLASS	207		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	207		Drive	DTR - Distronic																																	
E-CLASS	207		Drive	DSI - Direct select interface																																	
E-CLASS	207		Drive	AMG DRIVE UNIT																																	
E-CLASS	207		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	207		Chassis	Suspension																																	
E-CLASS	207		Chassis	ES - Electrical power steering																																	
E-CLASS	207		Chassis	FWGW - Chassis gateway																																	
E-CLASS	207		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	207		Body	BNS/BMS - Battery sensor																																	
E-CLASS	207		Body	WSS - Weight sensing system																																	
E-CLASS	207		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	207		Body	SCM [MRM] - Steering column module																																	
E-CLASS	207		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	207		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
E-CLASS	207		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	207		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	207		Body	Multifunction control unit																																	
E-CLASS	207		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
E-CLASS	207		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
E-CLASS	207		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	207		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	207		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	207		Body	CGW - Central gateway																																	
E-CLASS	207		Body	AHE - Trailer recognition																																	
E-CLASS	207		Body	AB - Airbag																																	
E-CLASS	207		Information	NBR-RF - Right front range radar																																	
E-CLASS	207		Information	NBR-LF - Left front range radar																																	
E-CLASS	207		Information	AVE-H - Rear audio video unit																																	
E-CLASS	207		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	207		Information	ZAN - Audio/COMAND display																																	
E-CLASS	207		Information	TV - TV tuner																																	
E-CLASS	207		Information	SOUND - Sound system																																	
E-CLASS	207		Information	SGR - Radar sensors control unit																																	
E-CLASS	207		Information	360' - Camera																																	
E-CLASS	207		Information	MFK - Multifunction camera																																	
E-CLASS	207		Information	RFK - Backup camera																																	
E-CLASS	207		Information	PTS - Parktronic system																																	
E-CLASS	207		Information	NSA - Night View Assist																																	
E-CLASS	207		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	207		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	207		Information	NAV - Navigation module																																	
E-CLASS	207		Information	MIF/UCI - Media interface																																	
E-CLASS	207		Information	ICI - InCar Internet																																	
E-CLASS	207		Information	IC - Instrument cluster																																	
E-CLASS	207		Information	DVD player																																	
E-CLASS	207		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
E-CLASS	207		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	207		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	207		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	207		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	207		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	207		Information	AUDIO/COMAND																																	
E-CLASS	207		Seat/Door	RVC/VDS - Convertible roof control																							V				V						
E-CLASS	207		Seat/Door	PSD/MSC - Sliding roof control																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
E-CLASS	207		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	207		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	207		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
E-CLASS	207		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
E-CLASS	207		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	207		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	207		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	212		Drive	SG-EM - Power electronics																																	
E-CLASS	212		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	212		Drive	ME/CDI/CNG - Engine control unit				V	V	V	V	V	V		V	V	V	V																			
E-CLASS	212		Drive	ETC - Electronic transmission control																																	
E-CLASS	212		Drive	ESM - Electronic selector module																																	
E-CLASS	212		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	212		Drive	ISM - Intelligent servo module																																	
E-CLASS	212		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	212		Drive	DTR - Distronic																																	
E-CLASS	212		Drive	DSI - Direct select interface																																	
E-CLASS	212		Drive	AMG DRIVE UNIT																																	
E-CLASS	212		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	212		Chassis	Suspension																																	
E-CLASS	212		Chassis	ES - Electrical power steering																																	
E-CLASS	212		Chassis	FWGW - Chassis gateway																																	
E-CLASS	212		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	212		Body	BNS/BMS - Battery sensor																																	
E-CLASS	212		Body	WSS - Weight sensing system																																	
E-CLASS	212		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	212		Body	SCM [MRM] - Steering column module																																	
E-CLASS	212		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	212		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
E-CLASS	212		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	OCP - Overhead control panel																																	
E-CLASS	212		Body	Multifunction control unit																																	
E-CLASS	212		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
E-CLASS	212		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	212		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
E-CLASS	212		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	212		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	212		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	212		Body	CGW - Central gateway																																	
E-CLASS	212		Body	AHE - Trailer recognition																																	
E-CLASS	212		Body	AB - Airbag																																	
E-CLASS	212		Information	Head-up display																																	
E-CLASS	212		Information	AVE-H - Rear audio video unit																																	
E-CLASS	212		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	212		Information	ZAN - Audio/COMAND display																																	
E-CLASS	212		Information	TV - TV tuner																																	
E-CLASS	212		Information	SOUND - Sound system																																	
E-CLASS	212		Information	SGR - Radar sensors control unit																																	
E-CLASS	212		Information	360' - Camera																																	
E-CLASS	212		Information	MFK - Multifunction camera																																	
E-CLASS	212		Information	RFK - Backup camera																																	
E-CLASS	212		Information	PTS - Parktronic system																																	
E-CLASS	212		Information	NSA - Night View Assist																																	
E-CLASS	212		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	212		Information	NBR-RF - Right front range radar																																	
E-CLASS	212		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	212		Information	NBR-LF - Left front range radar																																	
E-CLASS	212		Information	NAV - Navigation module																																	
E-CLASS	212		Information	MIF/UCI - Media interface																																	
E-CLASS	212		Information	ICI - InCar Internet																																	
E-CLASS	212		Information	IC - Instrument cluster																																	
E-CLASS	212		Information	DVD player																																	
E-CLASS	212		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
E-CLASS	212		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	212		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	212		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	212		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	212		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	212		Information	AUDIO/COMAND																																	
E-CLASS	212		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	212		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
E-CLASS	212		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	212		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	212		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	212		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DCM-RR - Door control module rear right		V																		V						V		V					
E-CLASS	212		Seat/Door	DCM-RL - Door control module rear left		V																		V		V						V					
E-CLASS	212		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
E-CLASS	212		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
E-CLASS	212		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	212		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	212		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	213		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	213		Drive	DTR - Distronic																																	
E-CLASS	213		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	213		Drive	HFPM - Haptic accelerator pedal module																																	
E-CLASS	213		Drive	AMG DRIVE UNIT																																	
E-CLASS	213		Drive	PTCU - Common powertrain controller																																	
E-CLASS	213		Drive	ME/CDI/CNG - Engine control unit																																	
E-CLASS	213		Drive	ETC - Electronic transmission control																																	
E-CLASS	213		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	213		Chassis	AIRMATIC PLUS																																	
E-CLASS	213		Chassis	ES - Electrical power steering																																	
E-CLASS	213		Chassis	Suspension																																	
E-CLASS	213		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	213		Body	MTAS - Mobile phone cradle																																	
E-CLASS	213		Body	AHE - Trailer recognition																																	
E-CLASS	213		Body	SCM [MRM] - Steering column module																																	
E-CLASS	213		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
E-CLASS	213		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
E-CLASS	213		Body	AB - Airbag																																	
E-CLASS	213		Body	OCP - Overhead control panel																																	
E-CLASS	213		Body	Multifunction control unit																																	
E-CLASS	213		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
E-CLASS	213		Body	SG-DDW - DC/DC converter control unit																																	
E-CLASS	213		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	213		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	213		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	213		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	213		Body	BNS/BMS - Battery sensor																																	
E-CLASS	213		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	213		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	213		Body	AML - Ambiance light																																	
E-CLASS	213		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	213		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	213		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
E-CLASS	213		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
E-CLASS	213		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	213		Seat/Door	HKS - Tailgate control																																	
E-CLASS	213		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	213		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DCM-RR - Door control module rear right																				V													
E-CLASS	213		Seat/Door	DCM-RL - Door control module rear left																				V													
E-CLASS	213		Seat/Door	DCM-FR - Door control module front right																				V													
E-CLASS	213		Seat/Door	DCM-FL - Door control module front left																				V													
E-CLASS	213		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	213		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	213		Information	TPAD - Touchpad		V																															
E-CLASS	213		Information	Sound generator for exhaust system																																	
E-CLASS	213		Information	SOUND - Sound system																																	
E-CLASS	213		Information	RFK - Backup camera																																	
E-CLASS	213		Information	PTS - Parktronic system																																	
E-CLASS	213		Information	MFK - Multifunction camera																																	
E-CLASS	213		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	213		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	213		Information	SGR - Radar sensors control unit																																	
E-CLASS	213		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
E-CLASS	213		Information	Head-up display																																	
E-CLASS	213		Information	AUDIO/COMAND																																	
E-CLASS	213		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
E-CLASS	213		Information	ZAN - Audio/COMAND display																																	
E-CLASS	213		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	213		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	140		Drive	ASF																																	
S-CLASS	140		Drive	ERE																																	
S-CLASS	140		Drive	ME1LI																																	
S-CLASS	140		Drive	ME1RE																																	
S-CLASS	140		Drive	HFM/ME2/LH																																	
S-CLASS	140		Drive	ETC - Electronic transmission control																																	
S-CLASS	140		Drive	ISC - Idle speed control																																	
S-CLASS	140		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	140		Chassis	BAS - Brake assist																																	
S-CLASS	140		Body	PSE - Pneumatic system equipment																																	
S-CLASS	140		Body	AB - Airbag																																	
S-CLASS	140		Information	PTS - Parktronic system																																	
S-CLASS	140		Information	IC - Instrument cluster																																	
S-CLASS	140		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	220		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V				V															
S-CLASS	220		Drive	ETC - Electronic transmission control																																	
S-CLASS	220		Drive	ESM - Electronic selector module																																	
S-CLASS	220		Drive	DTR - Distronic																																	
S-CLASS	220		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	220		Chassis	Suspension															V																		
S-CLASS	220		Chassis	PSE - Pneumatic system equipment																																	
S-CLASS	220		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	220		Body	UCP - Upper control panel																																	
S-CLASS	220		Body	System diagnosis																																	
S-CLASS	220		Body	SCM [MRM] - Steering column module																																	
S-CLASS	220		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	220		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
S-CLASS	220		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	220		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	220		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
S-CLASS	220		Body	OCP - Overhead control panel																																	
S-CLASS	220		Body	Multifunction control unit																																	
S-CLASS	220		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	220		Body	HSW/LRH - Steering wheel heater																																	
S-CLASS	220		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	220		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	220		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	220		Body	CGW - Central gateway																																	
S-CLASS	220		Body	AHE - Trailer recognition																																	
S-CLASS	220		Body	AB - Airbag																																	
S-CLASS	220		Information	TV - TV tuner																																	
S-CLASS	220		Information	PTS - Parktronic system																																	
S-CLASS	220		Information	NAV - Navigation module																																	
S-CLASS	220		Information	IC - Instrument cluster		V													V	V																	
S-CLASS	220		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	220		Information	AUDIO/COMAND																																	
S-CLASS	220		Information	AGW - Audio gateway																																	
S-CLASS	220		Seat/Door	OSB-R - Multicontour backrest rear																																	
S-CLASS	220		Seat/Door	OSB-FL - Multicontour backrest front left																																	
S-CLASS	220		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	220		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	220		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	220		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	220		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DCM-RR - Door control module rear right																												V					
S-CLASS	220		Seat/Door	DCM-RL - Door control module rear left																												V		V	V		
S-CLASS	220		Seat/Door	DCM-FR - Door control module front right																													V				
S-CLASS	220		Seat/Door	DCM-FL - Door control module front left																													V				
S-CLASS	220		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	220		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	220		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	221		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V		V	V	V	V																				
S-CLASS	221		Drive	ETC - Electronic transmission control																																	
S-CLASS	221		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	221		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
S-CLASS	221		Drive	HSG - Hybrid control unit																																	
S-CLASS	221		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	221		Drive	DTR - Distronic																																	
S-CLASS	221		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	221		Chassis	Suspension																																	
S-CLASS	221		Chassis	ES - Electrical power steering																																	
S-CLASS	221		Chassis	EFB - Electric parking brake																																	
S-CLASS	221		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	221		Body	WSS - Weight sensing system																																	
S-CLASS	221		Body	UCP - Upper control panel																																	
S-CLASS	221		Body	System diagnosis																																	
S-CLASS	221		Body	SG-DDW - DC/DC converter control unit																																	
S-CLASS	221		Body	SCM [MRM] - Steering column module																																	
S-CLASS	221		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	221		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	221		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	OCP - Overhead control panel																																	
S-CLASS	221		Body	Multifunction control unit																																	
S-CLASS	221		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	221		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	221		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	221		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	221		Body	CGW - Central gateway																																	
S-CLASS	221		Body	BNS/BMS - Battery sensor																																	
S-CLASS	221		Body	AHE - Trailer recognition																																	
S-CLASS	221		Body	AB - Airbag																																	
S-CLASS	221		Information	ZAN - Audio/COMAND display																																	
S-CLASS	221		Information	VCS - Voice control																																	
S-CLASS	221		Information	TV - TV tuner																																	
S-CLASS	221		Information	Tuner - Standard tuner																																	
S-CLASS	221		Information	SOUND - Sound system																																	
S-CLASS	221		Information	SGR - Radar sensors control unit																																	
S-CLASS	221		Information	MFK - Multifunction camera																																	
S-CLASS	221		Information	RFK - Backup camera																																	
S-CLASS	221		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
S-CLASS	221		Information	NSA - Night View Assist																																	
S-CLASS	221		Information	NBR-LF - Left front range radar																																	
S-CLASS	221		Information	NAV - Navigation module																																	
S-CLASS	221		Information	MIF/UCI - Media interface																																	
S-CLASS	221		Information	ICI - InCar Internet																																	
S-CLASS	221		Information	IC - Instrument cluster																																	
S-CLASS	221		Information	DVD player																																	
S-CLASS	221		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	221		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	221		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	221		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	221		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	221		Information	AVE-H - Rear audio video unit																																	
S-CLASS	221		Information	AUDIO/COMAND																																	
S-CLASS	221		Information	ASSYST PLUS - PLUS Active Service System																																	
S-CLASS	221		Information	ASSYST Active Service System																																	
S-CLASS	221		Seat/Door	TSG-MR - Right center door control unit																																	
S-CLASS	221		Seat/Door	TSG-ML - Left center door control unit																																	
S-CLASS	221		Seat/Door	TLC/GTO - Garage door opener																																	
S-CLASS	221		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	221		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
S-CLASS	221		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
S-CLASS	221		Seat/Door	HKS - Tailgate control																																	
S-CLASS	221		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	221		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	221		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	221		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	221		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	221		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	221		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	221		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	221		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	221		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	221		Air Conditioning	HBF - Rear control panel																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
S-CLASS	221		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	217		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	217		Drive	SG-EM - Power electronics																																	
S-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	217		Drive	DTR - Distronic																																	
S-CLASS	217		Drive	ISM - Intelligent servo module																																	
S-CLASS	217		Drive	PTCU - Common powertrain controller																																	
S-CLASS	217		Drive	ME/CDI/CNG - Engine control unit																																	
S-CLASS	217		Drive	ETC - Electronic transmission control																																	
S-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	217		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	217		Chassis	ES - Electrical power steering																																	
S-CLASS	217		Chassis	Suspension																																	
S-CLASS	217		Chassis	EFB - Electric parking brake																																	
S-CLASS	217		Information	TPAD - Touchpad		V																															
S-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	217		Information	360' - Camera																																	
S-CLASS	217		Information	SOUND - Sound system																																	
S-CLASS	217		Information	RFK - Backup camera																																	
S-CLASS	217		Information	SGR - Radar sensors control unit																																	
S-CLASS	217		Information	PTS - Parktronic system																																	
S-CLASS	217		Information	NSA - Night View Assist																																	
S-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	217		Information	NBR-RF - Right front range radar																																	
S-CLASS	217		Information	NBR-LF - Left front range radar																																	
S-CLASS	217		Information	MFK - Multifunction camera																																	
S-CLASS	217		Information	Head-up display																																	
S-CLASS	217		Information	AUDIO/COMAND																																	
S-CLASS	217		Information	ZAN - Audio/COMAND display																																	
S-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	217		Information	KAB - Camera cover																																	
S-CLASS	217		Information	IC - Instrument cluster																																	
S-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
S-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	217		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
S-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	AB - Airbag																																	
S-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	217		Body	BNS/BMS - Battery sensor																																	
S-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	217		Seat/Door	HKS - Tailgate control																																	
S-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	217		Seat/Door	DCM-FR - Door control module front right																				V													
S-CLASS	217		Seat/Door	DCM-FL - Door control module front left																				V													
S-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
S-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	222		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	222		Drive	SG-EM - Power electronics																																	
S-CLASS	222		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	222		Drive	DTR - Distronic																																	
S-CLASS	222		Drive	ISM - Intelligent servo module																																	
S-CLASS	222		Drive	PTCU - Common powertrain controller																																	
S-CLASS	222		Drive	ME/CDI/CNG - Engine control unit																																	
S-CLASS	222		Drive	ETC - Electronic transmission control																																	
S-CLASS	222		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	222		Chassis	ES - Electrical power steering																																	
S-CLASS	222		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	222		Chassis	Suspension																																	
S-CLASS	222		Chassis	EFB - Electric parking brake																																	
S-CLASS	222		Information	TPAD - Touchpad		V																															

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
S-CLASS	222		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	222		Information	360' - Camera																																	
S-CLASS	222		Information	Sound generator for exhaust system																																	
S-CLASS	222		Information	SOUND - Sound system																																	
S-CLASS	222		Information	RFK - Backup camera																																	
S-CLASS	222		Information	SGR - Radar sensors control unit																																	
S-CLASS	222		Information	PTS - Parktronic system																																	
S-CLASS	222		Information	NSA - Night View Assist																																	
S-CLASS	222		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	222		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	222		Information	NBR-RF - Right front range radar																																	
S-CLASS	222		Information	NBR-LF - Left front range radar																																	
S-CLASS	222		Information	MFK - Multifunction camera																																	
S-CLASS	222		Information	Head-up display																																	
S-CLASS	222		Information	AUDIO/COMAND																																	
S-CLASS	222		Information	AVE-H - Rear audio video unit																																	
S-CLASS	222		Information	ZAN - Audio/COMAND display																																	
S-CLASS	222		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	222		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	222		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	222		Information	KAB - Camera cover																																	
S-CLASS	222		Information	IC - Instrument cluster																																	
S-CLASS	222		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
S-CLASS	222		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	222		Body	AHE - Trailer recognition																																	
S-CLASS	222		Body	SCM [MRM] - Steering column module																																	
S-CLASS	222		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	AB - Airbag																																	
S-CLASS	222		Body	Multifunction control unit																																	
S-CLASS	222		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	222		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	222		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	222		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
S-CLASS	222		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	222		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
S-CLASS	222		Body	BNS/BMS - Battery sensor																																	
S-CLASS	222		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	222		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	222		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	222		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	222		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
S-CLASS	222		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
S-CLASS	222		Seat/Door	HKS - Tailgate control																																	
S-CLASS	222		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	222		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	222		Seat/Door	DCM-RR - Door control module rear right																			V														
S-CLASS	222		Seat/Door	DCM-RL - Door control module rear left																			V														
S-CLASS	222		Seat/Door	DCM-FR - Door control module front right																			V														
S-CLASS	222		Seat/Door	DCM-FL - Door control module front left																			V														
S-CLASS	222		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	222		Air Conditioning	AAC - Automatic air conditioning																																	
G-CLASS	461 - 38P Connector		Drive	EVE																																	
G-CLASS	461 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 38P Connector		Information	IC - Instrument cluster																																	
G-CLASS	461 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	461 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit																																	
G-CLASS	461 - 16P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	461 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	461 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	461 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	461 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	461 - 16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
G-CLASS	461 - 16P Connector		Body	CGW - Central gateway																																	
G-CLASS	461 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 16P Connector		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
G-CLASS	461 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	461 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	461 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 38P Connector		Drive	ME/CDI/CNG - Engine control unit			V		V	V	V	V	V	V								V															
G-CLASS	463 - 38P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	463 - 38P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 38P Connector		Drive	CC - Cruise control																																	
G-CLASS	463 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	463 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 38P Connector		Information	IC - Instrument cluster		V													V	V																	
G-CLASS	463 - 38P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 38P Connector		Information	APS - Auto pilot system																																	
G-CLASS	463 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V				V															
G-CLASS	463 - 16P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	463 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	463 - 16P Connector		Drive	SCR - Selective catalytic reduction																																	
G-CLASS	463 - 16P Connector		Drive	ISM - Intelligent servo module																																	
G-CLASS	463 - 16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
G-CLASS	463 - 16P Connector		Drive	DTR - Distronic																																	
G-CLASS	463 - 16P Connector		Drive	DSI - Direct select interface																																	
G-CLASS	463 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	463 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	463 - 16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
G-CLASS	463 - 16P Connector		Body	UCP - Upper control panel																																	
G-CLASS	463 - 16P Connector		Body	SCM [MRM] - Steering column module																																	
G-CLASS	463 - 16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
G-CLASS	463 - 16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
G-CLASS	463 - 16P Connector		Body	OCP - Overhead control panel																																	
G-CLASS	463 - 16P Connector		Body	Multifunction control unit																																	
G-CLASS	463 - 16P Connector		Body	HSW/LRH - Steering wheel heater																																	
G-CLASS	463 - 16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
G-CLASS	463 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	463 - 16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
G-CLASS	463 - 16P Connector		Body	AHE - Trailer recognition																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
G-CLASS	463 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 16P Connector		Information	ZAN - Audio/COMAND display																																	
G-CLASS	463 - 16P Connector		Information	TV - TV tuner																																	
G-CLASS	463 - 16P Connector		Information	SOUND - Sound system																																	
G-CLASS	463 - 16P Connector		Information	PTS - Parktronic system																																	
G-CLASS	463 - 16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NAV - Navigation module																																	
G-CLASS	463 - 16P Connector		Information	MIF/UCI - Media interface																																	
G-CLASS	463 - 16P Connector		Information	IC - Instrument cluster		V														V																	
G-CLASS	463 - 16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
G-CLASS	463 - 16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
G-CLASS	463 - 16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
G-CLASS	463 - 16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
G-CLASS	463 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	463 - 16P Connector		Seat/Door	HS - Seat heater																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RR - Door control module rear right		V																		V						V		V					
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RL - Door control module rear left		V																		V		V						V					
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V	V				
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V	V				
G-CLASS	463 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Air Conditioning	AAC - Automatic air conditioning																																	
GLA-CLASS	156		Drive	VG - Transfer case																																	
GLA-CLASS	156		Drive	ME/CDI/CNG - Engine control unit																																	
GLA-CLASS	156		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLA-CLASS	156		Drive	ETC - Electronic transmission control																																	
GLA-CLASS	156		Drive	DTR - Distronic																																	
GLA-CLASS	156		Drive	DSI - Direct select interface																																	
GLA-CLASS	156		Drive	PTCU - Common powertrain controller																																	
GLA-CLASS	156		Chassis	ABS/ESP - Electronic stability program																																	
GLA-CLASS	156		Chassis	ES - Electrical power steering																																	
GLA-CLASS	156		Chassis	EFB - Electric parking brake																																	
GLA-CLASS	156		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
GLA-CLASS	156		Body	SG-AWF - Collision prevention assist																																	
GLA-CLASS	156		Body	SCM [MRM] - Steering column module																																	
GLA-CLASS	156		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
GLA-CLASS	156		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	Multifunction control unit																																	
GLA-CLASS	156		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLA-CLASS	156		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLA-CLASS	156		Body	EZS/EIS - Electronic ignition lock																																	
GLA-CLASS	156		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLA-CLASS	156		Body	AHE - Trailer recognition																																	
GLA-CLASS	156		Body	AB - Airbag																																	
GLA-CLASS	156		Information	Head-up display																																	
GLA-CLASS	156		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLA-CLASS	156		Information	KAB - Camera cover																																	
GLA-CLASS	156		Information	ZAN - Audio/COMAND display																																	
GLA-CLASS	156		Information	TV - TV tuner																																	
GLA-CLASS	156		Information	SOUND - Sound system																																	
GLA-CLASS	156		Information	RFK - Backup camera																																	
GLA-CLASS	156		Information	MFK - Multifunction camera																																	
GLA-CLASS	156		Information	PTS - Parktronic system																																	
GLA-CLASS	156		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLA-CLASS	156		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLA-CLASS	156		Information	NAV - Navigation module																																	
GLA-CLASS	156		Information	MIF/UCI - Media interface																																	
GLA-CLASS	156		Information	IC - Instrument cluster																																	
GLA-CLASS	156		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
GLA-CLASS	156		Information	DAB/SDAR - Digital/Satellite radio																																	
GLA-CLASS	156		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLA-CLASS	156		Information	AUDIO/COMAND																																	
GLA-CLASS	156		Seat/Door	HKS - Tailgate control																																	
GLA-CLASS	156		Seat/Door	PSD/MSC - Sliding roof control																																	
GLA-CLASS	156		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLA-CLASS	156		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLA-CLASS	156		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
GLA-CLASS	156		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
GLA-CLASS	156		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLA-CLASS	156		Air Conditioning	AAC - Automatic air conditioning																																	
GLK-CLASS	204		Drive	ME/CDI/CNG - Engine control unit				V	V	V	V	V	V		V	V	V	V																			
GLK-CLASS	204		Drive	ETC - Electronic transmission control																																	
GLK-CLASS	204		Drive	ESM - Electronic selector module																																	
GLK-CLASS	204		Drive	SCR - Selective catalytic reduction																																	
GLK-CLASS	204		Drive	PTCU - Common powertrain controller																																	
GLK-CLASS	204		Drive	ISM - Intelligent servo module																																	
GLK-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
GLK-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLK-CLASS	204		Drive	DTR - Distronic																																	
GLK-CLASS	204		Drive	AMG DRIVE UNIT																																	
GLK-CLASS	204		Chassis	ABS/ESP - Electronic stability program																																	
GLK-CLASS	204		Chassis	Suspension																																	
GLK-CLASS	204		Chassis	ES - Electrical power steering																																	
GLK-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
GLK-CLASS	204		Body	WSS - Weight sensing system																																	
GLK-CLASS	204		Body	SCM [MRM] - Steering column module																																	
GLK-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLK-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
GLK-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	OCP - Overhead control panel																																	
GLK-CLASS	204		Body	Multifunction control unit																																	
GLK-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLK-CLASS	204		Body	Headlamp-R - Headlamp control unit																																	
GLK-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLK-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	
GLK-CLASS	204		Body	CGW - Central gateway																																	
GLK-CLASS	204		Body	AHE - Trailer recognition																																	
GLK-CLASS	204		Body	AB - Airbag																																	
GLK-CLASS	204		Information	Head-up display																																	
GLK-CLASS	204		Information	AVE-H - Rear audio video unit																																	
GLK-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLK-CLASS	204		Information	ZAN - Audio/COMAND display																																	
GLK-CLASS	204		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
GLK-CLASS	204		Information	Sound generator for exhaust system																																	
GLK-CLASS	204		Information	SOUND - Sound system																																	
GLK-CLASS	204		Information	SGR - Radar sensors control unit																																	
GLK-CLASS	204		Information	360' - Camera																																	
GLK-CLASS	204		Information	MFK - Multifunction camera																																	
GLK-CLASS	204		Information	RFK - Backup camera																																	
GLK-CLASS	204		Information	PTS - Parktronic system																																	
GLK-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLK-CLASS	204		Information	NBR-RF - Right front range radar																																	
GLK-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLK-CLASS	204		Information	NBR-LF - Left front range radar																																	
GLK-CLASS	204		Information	NAV - Navigation module																																	
GLK-CLASS	204		Information	MIF/UCI - Media interface																																	
GLK-CLASS	204		Information	ICI - InCar Internet																																	
GLK-CLASS	204		Information	IC - Instrument cluster																																	
GLK-CLASS	204		Information	DVD player																																	
GLK-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
GLK-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
GLK-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
GLK-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
GLK-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GLK-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLK-CLASS	204		Information	AUDIO/COMAND																																	
GLK-CLASS	204		Information	AMG Performance Media																																	
GLK-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
GLK-CLASS	204		Seat/Door	HKS - Tailgate control																																	
GLK-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLK-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLK-CLASS	204		Seat/Door	DCM-RR - Door control module rear right		V																		V						V		V					
GLK-CLASS	204		Seat/Door	DCM-RL - Door control module rear left		V																		V		V						V					
GLK-CLASS	204		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
GLK-CLASS	204		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
GLK-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLK-CLASS	204		Air Conditioning	AAC - Automatic air conditioning																																	
GLC-CLASS	253		Drive	SCR - Selective catalytic reduction																																	
GLC-CLASS	253		Drive	SG-EM - Power electronics																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
GLC-CLASS	253		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLC-CLASS	253		Drive	DTR - Distronic																																	
GLC-CLASS	253		Drive	ISM - Intelligent servo module																																	
GLC-CLASS	253		Drive	PTCU - Common powertrain controller																																	
GLC-CLASS	253		Drive	ME/CDI/CNG - Engine control unit																																	
GLC-CLASS	253		Drive	ETC - Electronic transmission control																																	
GLC-CLASS	253		Chassis	TPM - Tire pressure monitor																																	
GLC-CLASS	253		Chassis	AIRMATIC PLUS																																	
GLC-CLASS	253		Chassis	ES - Electrical power steering																																	
GLC-CLASS	253		Chassis	Suspension																																	
GLC-CLASS	253		Chassis	ABS/ESP - Electronic stability program																																	
GLC-CLASS	253		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLC-CLASS	253		Body	AHE - Trailer recognition																																	
GLC-CLASS	253		Body	SCM [MRM] - Steering column module																																	
GLC-CLASS	253		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	AB - Airbag																																	
GLC-CLASS	253		Body	Multifunction control unit																																	
GLC-CLASS	253		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLC-CLASS	253		Body	Headlamp-R - Headlamp control unit																																	
GLC-CLASS	253		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLC-CLASS	253		Body	SG-AWF - Collision prevention assist																																	
GLC-CLASS	253		Body	EZS/EIS - Electronic ignition lock																																	
GLC-CLASS	253		Body	BNS/BMS - Battery sensor																																	
GLC-CLASS	253		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLC-CLASS	253		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLC-CLASS	253		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLC-CLASS	253		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLC-CLASS	253		Seat/Door	PSD/MSC - Sliding roof control																																	
GLC-CLASS	253		Seat/Door	HKS - Tailgate control																																	
GLC-CLASS	253		Seat/Door	DCM-RR - Door control module rear right																			V														
GLC-CLASS	253		Seat/Door	DCM-RL - Door control module rear left																			V														
GLC-CLASS	253		Seat/Door	DCM-FR - Door control module front right																			V														
GLC-CLASS	253		Seat/Door	DCM-FL - Door control module front left																			V														
GLC-CLASS	253		Information	TPAD - Touchpad		V																															
GLC-CLASS	253		Information	DAB/SDAR - Digital/Satellite radio																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
GLC-CLASS	253		Information	360' - Camera																																	
GLC-CLASS	253		Information	Sound generator for exhaust system																																	
GLC-CLASS	253		Information	SOUND - Sound system																																	
GLC-CLASS	253		Information	RFK - Backup camera																																	
GLC-CLASS	253		Information	SGR - Radar sensors control unit																																	
GLC-CLASS	253		Information	PTS - Parktronic system																																	
GLC-CLASS	253		Information	NBR-RF - Right front range radar																																	
GLC-CLASS	253		Information	NBR-LF - Left front range radar																																	
GLC-CLASS	253		Information	MFK - Multifunction camera																																	
GLC-CLASS	253		Information	IC - Instrument cluster																																	
GLC-CLASS	253		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLC-CLASS	253		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLC-CLASS	253		Information	Head-up display																																	
GLC-CLASS	253		Information	AUDIO/COMAND																																	
GLC-CLASS	253		Information	SG-MSND - Engine sound																																	
GLC-CLASS	253		Information	ZAN - Audio/COMAND display																																	
GLC-CLASS	253		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLC-CLASS	253		Information	KAB - Camera cover																																	
GLC-CLASS	253		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
GLC-CLASS	253		Information	AMG Performance Media																																	
GLC-CLASS	253		Air Conditioning	AAC - Automatic air conditioning																																	
GLE-CLASS	292		Drive	SCR - Selective catalytic reduction																																	
GLE-CLASS	292		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLE-CLASS	292		Drive	ISM - Intelligent servo module																																	
GLE-CLASS	292		Drive	DTR - Distronic																																	
GLE-CLASS	292		Drive	ME/CDI/CNG - Engine control unit																																	
GLE-CLASS	292		Drive	ETC - Electronic transmission control																																	
GLE-CLASS	292		Chassis	TPM - Tire pressure monitor																																	
GLE-CLASS	292		Chassis	FWGW - Chassis gateway																																	
GLE-CLASS	292		Chassis	ABS/ESP - Electronic stability program																																	
GLE-CLASS	292		Chassis	ES - Electrical power steering																																	
GLE-CLASS	292		Chassis	EFB - Electric parking brake																																	
GLE-CLASS	292		Chassis	Suspension																																	
GLE-CLASS	292		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLE-CLASS	292		Body	AHE - Trailer recognition																																	
GLE-CLASS	292		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
GLE-CLASS	292		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLE-CLASS	292		Body	AB - Airbag																																	
GLE-CLASS	292		Body	Multifunction control unit																																	
GLE-CLASS	292		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLE-CLASS	292		Body	Headlamp-R - Headlamp control unit																																	
GLE-CLASS	292		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLE-CLASS	292		Body	SG-AWF - Collision prevention assist																																	
GLE-CLASS	292		Body	EZS/EIS - Electronic ignition lock																																	
GLE-CLASS	292		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
GLE-CLASS	292		Information	TPAD - Touchpad		V																															
GLE-CLASS	292		Information	DAB/SDAR - Digital/Satellite radio																																	
GLE-CLASS	292		Information	360' - Camera																																	
GLE-CLASS	292		Information	SOUND - Sound system																																	
GLE-CLASS	292		Information	RFK - Backup camera																																	
GLE-CLASS	292		Information	SGR - Radar sensors control unit																																	
GLE-CLASS	292		Information	PTS - Parktronic system																																	
GLE-CLASS	292		Information	MFK - Multifunction camera																																	
GLE-CLASS	292		Information	NBR-RF - Right front range radar																																	
GLE-CLASS	292		Information	NBR-LF - Left front range radar																																	
GLE-CLASS	292		Information	IC - Instrument cluster																																	
GLE-CLASS	292		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLE-CLASS	292		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLE-CLASS	292		Information	Head-up display																																	
GLE-CLASS	292		Information	AUDIO/COMAND																																	
GLE-CLASS	292		Information	AVE-H - Rear audio video unit																																	
GLE-CLASS	292		Information	DVD player																																	
GLE-CLASS	292		Information	SG-MSND - Engine sound																																	
GLE-CLASS	292		Information	ZAN - Audio/COMAND display																																	
GLE-CLASS	292		Information	D-FOR - Display in right rear passenger																																	
GLE-CLASS	292		Information	D-FOL - Display in left rear passenger																																	
GLE-CLASS	292		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLE-CLASS	292		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
GLE-CLASS	292		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLE-CLASS	292		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
GLE-CLASS	292		Seat/Door	PSD/MSC - Sliding roof control																																	
GLE-CLASS	292		Seat/Door	HKS - Tailgate control																																	
GLE-CLASS	292		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DCM-RR - Door control module rear right		V																		V						V		V					
GLE-CLASS	292		Seat/Door	DCM-RL - Door control module rear left		V																		V		V						V					
GLE-CLASS	292		Seat/Door	DCM-FR - Door control module front right		V																		V						V		V					
GLE-CLASS	292		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
GLE-CLASS	292		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLE-CLASS	292		Air Conditioning	HBF - Rear control panel																																	
GLE-CLASS	292		Air Conditioning	AAC - Automatic air conditioning																																	
GL-CLASS	164		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V				V															
GL-CLASS	164		Drive	ETC - Electronic transmission control																																	
GL-CLASS	164		Drive	VG - Transfer case																																	
GL-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
GL-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
GL-CLASS	164		Drive	SCR - Selective catalytic reduction																																	
GL-CLASS	164		Drive	ISM - Intelligent servo module																																	
GL-CLASS	164		Drive	HSG - Hybrid control unit																																	
GL-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
GL-CLASS	164		Drive	DTR - Distronic																																	
GL-CLASS	164		Chassis	ABS/ESP - Electronic stability program																																	
GL-CLASS	164		Chassis	Suspension																																	
GL-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
GL-CLASS	164		Chassis	ES - Electrical power steering																																	
GL-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	164		Body	WSS - Weight sensing system																																	
GL-CLASS	164		Body	UCP - Upper control panel																																	
GL-CLASS	164		Body	System diagnosis																																	
GL-CLASS	164		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GL-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
GL-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
GL-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	164		Body	CGW - Central gateway																																	
GL-CLASS	164		Body	AB - Airbag																																	
GL-CLASS	164		Information	TV - TV tuner																																	
GL-CLASS	164		Information	SOUND - Sound system																																	
GL-CLASS	164		Information	RFK - Backup camera																																	
GL-CLASS	164		Information	PTS - Parktronic system																																	
GL-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	164		Information	NAV - Navigation module																																	
GL-CLASS	164		Information	MIF/UCI - Media interface																																	
GL-CLASS	164		Information	IC - Instrument cluster		V														V																	
GL-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GL-CLASS	164		Information	CM - Compass module																																	
GL-CLASS	164		Information	AVE-H - Rear audio video unit																																	
GL-CLASS	164		Information	AUDIO/COMAND																																	
GL-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
GL-CLASS	164		Information	ASSYST Active Service System																V																	
GL-CLASS	164		Information	AGW - Audio gateway																																	
GL-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																							V				V						
GL-CLASS	164		Seat/Door	HS - Seat heater																																	
GL-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
GL-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DCM-FR - Door control module front right																													V	V			

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
GL-CLASS	164		Seat/Door	DCM-FL - Door control module front left																													V	V			
GL-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GL-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
GL-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
GL-CLASS	166		Drive	SG-EM - Power electronics																																	
GL-CLASS	166		Drive	PTCU - Common powertrain controller																																	
GL-CLASS	166		Drive	ME/CDI/CNG - Engine control unit																																	
GL-CLASS	166		Drive	ETC - Electronic transmission control																																	
GL-CLASS	166		Drive	VG - Transfer case																																	
GL-CLASS	166		Drive	SCR - Selective catalytic reduction																																	
GL-CLASS	166		Drive	ISM - Intelligent servo module																																	
GL-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	166		Drive	DTR - Distronic																																	
GL-CLASS	166		Chassis	ABS/ESP - Electronic stability program																																	
GL-CLASS	166		Chassis	Suspension																																	
GL-CLASS	166		Chassis	ES - Electrical power steering																																	
GL-CLASS	166		Chassis	EFB - Electric parking brake																																	
GL-CLASS	166		Chassis	FWGW - Chassis gateway																																	
GL-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
GL-CLASS	166		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
GL-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	Multifunction control unit																																	
GL-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GL-CLASS	166		Body	AHE - Trailer recognition																																	
GL-CLASS	166		Body	AB - Airbag																																	
GL-CLASS	166		Information	Sound generator for exhaust system																																	
GL-CLASS	166		Information	Head-up display																																	
GL-CLASS	166		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
GL-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GL-CLASS	166		Information	ZAN - Audio/COMAND display																																	
GL-CLASS	166		Information	TV - TV tuner																																	
GL-CLASS	166		Information	SOUND - Sound system																																	
GL-CLASS	166		Information	SGR - Radar sensors control unit																																	
GL-CLASS	166		Information	360' - Camera																																	
GL-CLASS	166		Information	RFK - Backup camera																																	
GL-CLASS	166		Information	MFK - Multifunction camera																																	
GL-CLASS	166		Information	PTS - Parktronic system																																	
GL-CLASS	166		Information	NSA - Night View Assist																																	
GL-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	166		Information	NBR-RF - Right front range radar																																	
GL-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	166		Information	NBR-LF - Left front range radar																																	
GL-CLASS	166		Information	NAV - Navigation module																																	
GL-CLASS	166		Information	MIF/UCI - Media interface																																	
GL-CLASS	166		Information	IC - Instrument cluster																																	
GL-CLASS	166		Information	DVD player																																	
GL-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
GL-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GL-CLASS	166		Information	AUDIO/COMAND																																	
GL-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
GL-CLASS	166		Seat/Door	HKS - Tailgate control																																	
GL-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DCM-RR - Door control module rear right		V																		V						V		V					
GL-CLASS	166		Seat/Door	DCM-RL - Door control module rear left		V																		V		V						V					
GL-CLASS	166		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
GL-CLASS	166		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
GL-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
GL-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
GL-CLASS	166		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	163		Drive	ME/CDI/CNG - Engine control unit			V		V	V	V	V	V	V								V															
M-CLASS	163		Drive	ETC - Electronic transmission control																																	
M-CLASS	163		Drive	ESM - Electronic selector module																																	
M-CLASS	163		Drive	VG - Transfer case																																	
M-CLASS	163		Chassis	ABS/ESP - Electronic stability program																																	
M-CLASS	163		Chassis	VP - Vacuum pump brake booster																																	
M-CLASS	163		Chassis	BAS - Brake assist																																	
M-CLASS	163		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	163		Body	AB - Airbag																																	
M-CLASS	163		Body	AAM - All activity module																																	
M-CLASS	163		Information	PTS - Parktronic system																																	
M-CLASS	163		Information	IC - Instrument cluster																V																	
M-CLASS	163		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	163		Information	AUDIO/COMAND																																	
M-CLASS	163		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	163		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V				V															
M-CLASS	164		Drive	ETC - Electronic transmission control																																	
M-CLASS	164		Drive	VG - Transfer case																																	
M-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
M-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
M-CLASS	164		Drive	SCR - Selective catalytic reduction																																	
M-CLASS	164		Drive	ISM - Intelligent servo module																																	
M-CLASS	164		Drive	HSG - Hybrid control unit																																	
M-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
M-CLASS	164		Drive	DTR - Distronic																																	
M-CLASS	164		Chassis	ABS/ESP - Electronic stability program																																	
M-CLASS	164		Chassis	Suspension																																	
M-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
M-CLASS	164		Chassis	ES - Electrical power steering																																	
M-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	164		Body	WSS - Weight sensing system																																	
M-CLASS	164		Body	UCP - Upper control panel																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
M-CLASS	164		Body	System diagnosis																																	
M-CLASS	164		Body	SCM [MRM] - Steering column module																																	
M-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
M-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	OCP - Overhead control panel																																	
M-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
M-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	164		Body	CGW - Central gateway																																	
M-CLASS	164		Body	AB - Airbag																																	
M-CLASS	164		Information	TV - TV tuner																																	
M-CLASS	164		Information	SOUND - Sound system																																	
M-CLASS	164		Information	RFK - Backup camera																																	
M-CLASS	164		Information	PTS - Parktronic system																																	
M-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	164		Information	NAV - Navigation module																																	
M-CLASS	164		Information	MIF/UCI - Media interface																																	
M-CLASS	164		Information	IC - Instrument cluster		V														V																	
M-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
M-CLASS	164		Information	CM - Compass module																																	
M-CLASS	164		Information	AVE-H - Rear audio video unit																																	
M-CLASS	164		Information	AUDIO/COMAND																																	
M-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
M-CLASS	164		Information	ASSYST Active Service System																V																	
M-CLASS	164		Information	AGW - Audio gateway																																	
M-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																							V				V						
M-CLASS	164		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
M-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
M-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DCM-FR - Door control module front right																												V	V				
M-CLASS	164		Seat/Door	DCM-FL - Door control module front left																												V	V				
M-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
M-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	166		Drive	SG-EM - Power electronics																																	
M-CLASS	166		Drive	ME/CDI/CNG - Engine control unit																																	
M-CLASS	166		Drive	ETC - Electronic transmission control																																	
M-CLASS	166		Drive	VG - Transfer case																																	
M-CLASS	166		Drive	SCR - Selective catalytic reduction																																	
M-CLASS	166		Drive	PTCU - Common powertrain controller																																	
M-CLASS	166		Drive	ISM - Intelligent servo module																																	
M-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	166		Drive	DTR - Distronic																																	
M-CLASS	166		Chassis	ABS/ESP - Electronic stability program																																	
M-CLASS	166		Chassis	Suspension																																	
M-CLASS	166		Chassis	ES - Electrical power steering																																	
M-CLASS	166		Chassis	EFB - Electric parking brake																																	
M-CLASS	166		Chassis	FWGW - Chassis gateway																																	
M-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
M-CLASS	166		Body	SCM [MRM] - Steering column module																																	
M-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
M-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	Multifunction control unit																																	
M-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
M-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
M-CLASS	166		Body	AHE - Trailer recognition																																	
M-CLASS	166		Body	AB - Airbag																																	
M-CLASS	166		Information	Sound generator for exhaust system																																	
M-CLASS	166		Information	Head-up display																																	
M-CLASS	166		Information	AVE-H - Rear audio video unit																																	
M-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
M-CLASS	166		Information	ZAN - Audio/COMAND display																																	
M-CLASS	166		Information	TV - TV tuner																																	
M-CLASS	166		Information	SOUND - Sound system																																	
M-CLASS	166		Information	SGR - Radar sensors control unit																																	
M-CLASS	166		Information	360' - Camera																																	
M-CLASS	166		Information	RFK - Backup camera																																	
M-CLASS	166		Information	MFK - Multifunction camera																																	
M-CLASS	166		Information	PTS - Parktronic system																																	
M-CLASS	166		Information	NSA - Night View Assist																																	
M-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	166		Information	NBR-RF - Right front range radar																																	
M-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	166		Information	NBR-LF - Left front range radar																																	
M-CLASS	166		Information	NAV - Navigation module																																	
M-CLASS	166		Information	MIF/UCI - Media interface																																	
M-CLASS	166		Information	IC - Instrument cluster																																	
M-CLASS	166		Information	DVD player																																	
M-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
M-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
M-CLASS	166		Information	AUDIO/COMAND																																	
M-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
M-CLASS	166		Seat/Door	HKS - Tailgate control																																	
M-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
M-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	166		Seat/Door	DCM-RR - Door control module rear right		V																		V						V		V					
M-CLASS	166		Seat/Door	DCM-RL - Door control module rear left		V																		V		V						V					
M-CLASS	166		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
M-CLASS	166		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
M-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
M-CLASS	166		Air Conditioning	AAC - Automatic air conditioning																																	
R-CLASS	251		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V				V															
R-CLASS	251		Drive	ETC - Electronic transmission control																																	
R-CLASS	251		Drive	SCR - Selective catalytic reduction																																	
R-CLASS	251		Drive	ISM - Intelligent servo module																																	
R-CLASS	251		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
R-CLASS	251		Drive	DTR - Distronic																																	
R-CLASS	251		Chassis	ABS/ESP - Electronic stability program																																	
R-CLASS	251		Chassis	Suspension																																	
R-CLASS	251		Chassis	ES - Electrical power steering																																	
R-CLASS	251		Chassis	TPM - Tire pressure monitor																																	
R-CLASS	251		Body	WSS - Weight sensing system																																	
R-CLASS	251		Body	UCP - Upper control panel																																	
R-CLASS	251		Body	System diagnosis																																	
R-CLASS	251		Body	SCM [MRM] - Steering column module																																	
R-CLASS	251		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
R-CLASS	251		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
R-CLASS	251		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	OCP - Overhead control panel																																	
R-CLASS	251		Body	LCP/HBF - Lower/Rear control panel																																	
R-CLASS	251		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
R-CLASS	251		Body	Headlamp-R - Headlamp control unit																																	
R-CLASS	251		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
R-CLASS	251		Body	EZS/EIS - Electronic ignition lock																																	
R-CLASS	251		Body	CGW - Central gateway																																	
R-CLASS	251		Body	AB - Airbag																																	
R-CLASS	251		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
R-CLASS	251		Information	SOUND - Sound system																																	
R-CLASS	251		Information	RFK - Backup camera																																	
R-CLASS	251		Information	PTS - Parktronic system																																	
R-CLASS	251		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
R-CLASS	251		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
R-CLASS	251		Information	NAV - Navigation module																																	
R-CLASS	251		Information	MIF/UCI - Media interface																																	
R-CLASS	251		Information	IC - Instrument cluster		V														V																	
R-CLASS	251		Information	DTA - Mbrace or TELEAID/GPS Box																																	
R-CLASS	251		Information	D-FOR - Display in right rear passenger																																	
R-CLASS	251		Information	D-FOL - Display in left rear passenger																																	
R-CLASS	251		Information	DAB/SDAR - Digital/Satellite radio																																	
R-CLASS	251		Information	CTEL/TEL - Cellular/Mobile telephone																																	
R-CLASS	251		Information	CM - Compass module																																	
R-CLASS	251		Information	AVE-H - Rear audio video unit																																	
R-CLASS	251		Information	AUDIO/COMAND																																	
R-CLASS	251		Information	ASSYST PLUS - PLUS Active Service System																																	
R-CLASS	251		Information	ASSYST Active Service System																V																	
R-CLASS	251		Information	AGW - Audio gateway																																	
R-CLASS	251		Seat/Door	REDC/RWT - Rear end door control module																							V				V						
R-CLASS	251		Seat/Door	HS - Seat heater																																	
R-CLASS	251		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
R-CLASS	251		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
R-CLASS	251		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
R-CLASS	251		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DCM-FR - Door control module front right																												V	V				
R-CLASS	251		Seat/Door	DCM-FL - Door control module front left																												V	V				
R-CLASS	251		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
R-CLASS	251		Air Conditioning	AAC - Automatic air conditioning																																	
CLA-CLASS	117		Drive	VG - Transfer case																																	
CLA-CLASS	117		Drive	ME/CDI/CNG - Engine control unit																																	
CLA-CLASS	117		Drive	ETC - Electronic transmission control																																	
CLA-CLASS	117		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLA-CLASS	117		Drive	DTR - Distronic																																	
CLA-CLASS	117		Drive	DSI - Direct select interface																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
CLA-CLASS	117		Drive	PTCU - Common powertrain controller																																	
CLA-CLASS	117		Chassis	ABS/ESP - Electronic stability program																																	
CLA-CLASS	117		Chassis	ES - Electrical power steering																																	
CLA-CLASS	117		Chassis	EFB - Electric parking brake																																	
CLA-CLASS	117		Chassis	TPM - Tire pressure monitor																																	
CLA-CLASS	117		Body	SG-AWF - Collision prevention assist																																	
CLA-CLASS	117		Body	SCM [MRM] - Steering column module																																	
CLA-CLASS	117		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
CLA-CLASS	117		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	Multifunction control unit																																	
CLA-CLASS	117		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLA-CLASS	117		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLA-CLASS	117		Body	EZS/EIS - Electronic ignition lock																																	
CLA-CLASS	117		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CLA-CLASS	117		Body	AHE - Trailer recognition																																	
CLA-CLASS	117		Body	AB - Airbag																																	
CLA-CLASS	117		Information	Head-up display																																	
CLA-CLASS	117		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLA-CLASS	117		Information	KAB - Camera cover																																	
CLA-CLASS	117		Information	ZAN - Audio/COMAND display																																	
CLA-CLASS	117		Information	TV - TV tuner																																	
CLA-CLASS	117		Information	SOUND - Sound system																																	
CLA-CLASS	117		Information	RFK - Backup camera																																	
CLA-CLASS	117		Information	MFK - Multifunction camera																																	
CLA-CLASS	117		Information	PTS - Parktronic system																																	
CLA-CLASS	117		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLA-CLASS	117		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLA-CLASS	117		Information	NAV - Navigation module																																	
CLA-CLASS	117		Information	MIF/UCI - Media interface																																	
CLA-CLASS	117		Information	IC - Instrument cluster																																	
CLA-CLASS	117		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
CLA-CLASS	117		Information	DAB/SDAR - Digital/Satellite radio																																	
CLA-CLASS	117		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLA-CLASS	117		Information	AUDIO/COMAND																																	
CLA-CLASS	117		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
CLA-CLASS	117		Seat/Door	PSD/MSC - Sliding roof control																																	
CLA-CLASS	117		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLA-CLASS	117		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLA-CLASS	117		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
CLA-CLASS	117		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
CLA-CLASS	117		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLA-CLASS	117		Air Conditioning	AAC - Automatic air conditioning																																	
CLK-CLASS	208		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V								V															
CLK-CLASS	208		Drive	ETC - Electronic transmission control																																	
CLK-CLASS	208		Drive	ESM - Electronic selector module																																	
CLK-CLASS	208		Chassis	PSE - Pneumatic system equipment																																	
CLK-CLASS	208		Chassis	ABS/ESP - Electronic stability program																																	
CLK-CLASS	208		Chassis	VP - Vacuum pump brake booster																																	
CLK-CLASS	208		Chassis	BAS - Brake assist																																	
CLK-CLASS	208		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	208		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	208		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	208		Body	OCP - Overhead control panel																																	
CLK-CLASS	208		Body	AB - Airbag																																	
CLK-CLASS	208		Information	TV - TV tuner																																	
CLK-CLASS	208		Information	PTS - Parktronic system																																	
CLK-CLASS	208		Information	NAV - Navigation module																																	
CLK-CLASS	208		Information	IC - Instrument cluster		V														V	V																
CLK-CLASS	208		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	208		Information	AUDIO/COMAND																																	
CLK-CLASS	208		Information	APS - Auto pilot system																																	
CLK-CLASS	208		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	208		Air Conditioning	AAC - Automatic air conditioning																																	
CLK-CLASS	208		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	208		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	208		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	208		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V				V															
CLK-CLASS	209		Drive	ETC - Electronic transmission control																																	
CLK-CLASS	209		Drive	ESM - Electronic selector module																																	
CLK-CLASS	209		Drive	DTR - Distronic																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
CLK-CLASS	209		Chassis	ABS/ESP - Electronic stability program																																	
CLK-CLASS	209		Chassis	TPM - Tire pressure monitor																																	
CLK-CLASS	209		Body	WSS - Weight sensing system																																	
CLK-CLASS	209		Body	UCP - Upper control panel																																	
CLK-CLASS	209		Body	SCM [MRM] - Steering column module																																	
CLK-CLASS	209		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLK-CLASS	209		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	209		Body	RCM - Rear control module																													V				
CLK-CLASS	209		Body	OCP - Overhead control panel																																	
CLK-CLASS	209		Body	Multifunction control unit																																	
CLK-CLASS	209		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	209		Body	Headlamp-R - Headlamp control unit																																	
CLK-CLASS	209		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLK-CLASS	209		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	209		Body	BNS/BMS - Battery sensor																																	
CLK-CLASS	209		Body	AHE - Trailer recognition																																	
CLK-CLASS	209		Body	AB - Airbag																																	
CLK-CLASS	209		Information	TV - TV tuner																																	
CLK-CLASS	209		Information	PTS - Parktronic system																																	
CLK-CLASS	209		Information	NAV - Navigation module																																	
CLK-CLASS	209		Information	IC - Instrument cluster		V														V																	
CLK-CLASS	209		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	209		Information	AUDIO/COMAND																																	
CLK-CLASS	209		Information	AGW - Audio gateway																																	
CLK-CLASS	209		Seat/Door	RVC/VDS - Convertible roof control																													V				
CLK-CLASS	209		Seat/Door	REDC/RWT - Rear end door control module																							V				V						
CLK-CLASS	209		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	209		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Seat/Door	DCM-FR - Door control module front right																												V	V				
CLK-CLASS	209		Seat/Door	DCM-FL - Door control module front left																												V	V				
CLK-CLASS	209		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	209		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	219		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V				V															
CLS-CLASS	219		Drive	ETC - Electronic transmission control																																	
CLS-CLASS	219		Drive	ESM - Electronic selector module																																	
CLS-CLASS	219		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
CLS-CLASS	219		Drive	DTR - Distronic																																	
CLS-CLASS	219		Chassis	ABS/ESP - Electronic stability program																																	
CLS-CLASS	219		Chassis	Suspension																																	
CLS-CLASS	219		Chassis	SBC - Sensotronic Brake Control																																	
CLS-CLASS	219		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	219		Body	WSS - Weight sensing system																																	
CLS-CLASS	219		Body	UCP - Upper control panel																																	
CLS-CLASS	219		Body	System diagnosis																																	
CLS-CLASS	219		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	219		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	219		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CLS-CLASS	219		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLS-CLASS	219		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	OCP - Overhead control panel																																	
CLS-CLASS	219		Body	LCP/HBF - Lower/Rear control panel																																	
CLS-CLASS	219		Body	LAE [LAA] - Loading floor automatically extendable																																	
CLS-CLASS	219		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	219		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	219		Body	CGW - Central gateway																																	
CLS-CLASS	219		Body	BNS/BMS - Battery sensor																																	
CLS-CLASS	219		Body	AB - Airbag																																	
CLS-CLASS	219		Information	TV - TV tuner																																	
CLS-CLASS	219		Information	SOUND - Sound system																																	
CLS-CLASS	219		Information	PTS - Parktronic system																																	
CLS-CLASS	219		Information	MIF/UCI - Media interface																																	
CLS-CLASS	219		Information	IC - Instrument cluster		V														V																	
CLS-CLASS	219		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	219		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	219		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	219		Information	AUDIO/COMAND																																	
CLS-CLASS	219		Information	ASSYST PLUS - PLUS Active Service System																																	
CLS-CLASS	219		Information	ASSYST Active Service System																V																	
CLS-CLASS	219		Information	AGW - Audio gateway																																	
CLS-CLASS	219		Seat/Door	REDC/RWT - Rear end door control module																							V				V						
CLS-CLASS	219		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
CLS-CLASS	219		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	219		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	219		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	219		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DCM-RR - Door control module rear right																												V					
CLS-CLASS	219		Seat/Door	DCM-RL - Door control module rear left																												V					
CLS-CLASS	219		Seat/Door	DCM-FR - Door control module front right																												V	V				
CLS-CLASS	219		Seat/Door	DCM-FL - Door control module front left																												V	V				
CLS-CLASS	219		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	219		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	218		Drive	ME/CDI/CNG - Engine control unit				V	V	V	V	V	V		V	V	V	V																			
CLS-CLASS	218		Drive	ETC - Electronic transmission control																																	
CLS-CLASS	218		Drive	ESM - Electronic selector module																																	
CLS-CLASS	218		Drive	SCR - Selective catalytic reduction																																	
CLS-CLASS	218		Drive	ISM - Intelligent servo module																																	
CLS-CLASS	218		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLS-CLASS	218		Drive	DTR - Distronic																																	
CLS-CLASS	218		Drive	DSI - Direct select interface																																	
CLS-CLASS	218		Drive	AMG DRIVE UNIT																																	
CLS-CLASS	218		Chassis	ABS/ESP - Electronic stability program																																	
CLS-CLASS	218		Chassis	Suspension																																	
CLS-CLASS	218		Chassis	ES - Electrical power steering																																	
CLS-CLASS	218		Chassis	FWGW - Chassis gateway																																	
CLS-CLASS	218		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	218		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
CLS-CLASS	218		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
CLS-CLASS	218		Body	WSS - Weight sensing system																																	
CLS-CLASS	218		Body	SG-AWF - Collision prevention assist																																	
CLS-CLASS	218		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	218		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	218		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
CLS-CLASS	218		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	OCP - Overhead control panel																																	
CLS-CLASS	218		Body	Multifunction control unit																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
CLS-CLASS	218		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLS-CLASS	218		Body	HSW/LRH - Steering wheel heater																																	
CLS-CLASS	218		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
CLS-CLASS	218		Body	Headlamp-R - Headlamp control unit																																	
CLS-CLASS	218		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	218		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	218		Body	CGW - Central gateway																																	
CLS-CLASS	218		Body	AHE - Trailer recognition																																	
CLS-CLASS	218		Body	AB - Airbag																																	
CLS-CLASS	218		Information	360' - Camera																																	
CLS-CLASS	218		Information	AVE-H - Rear audio video unit																																	
CLS-CLASS	218		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLS-CLASS	218		Information	ZAN - Audio/COMAND display																																	
CLS-CLASS	218		Information	TV - TV tuner																																	
CLS-CLASS	218		Information	SOUND - Sound system																																	
CLS-CLASS	218		Information	SGR - Radar sensors control unit																																	
CLS-CLASS	218		Information	MFK - Multifunction camera																																	
CLS-CLASS	218		Information	RFK - Backup camera																																	
CLS-CLASS	218		Information	PTS - Parktronic system																																	
CLS-CLASS	218		Information	NSA - Night View Assist																																	
CLS-CLASS	218		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLS-CLASS	218		Information	NBR-RF - Right front range radar																																	
CLS-CLASS	218		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLS-CLASS	218		Information	NBR-LF - Left front range radar																																	
CLS-CLASS	218		Information	NAV - Navigation module																																	
CLS-CLASS	218		Information	MIF/UCI - Media interface																																	
CLS-CLASS	218		Information	ICI - InCar Internet																																	
CLS-CLASS	218		Information	IC - Instrument cluster																																	
CLS-CLASS	218		Information	DVD player																																	
CLS-CLASS	218		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
CLS-CLASS	218		Information	D-FOR - Display in right rear passenger																																	
CLS-CLASS	218		Information	D-FOL - Display in left rear passenger																																	
CLS-CLASS	218		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	218		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	218		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLS-CLASS	218		Information	AUDIO/COMAND																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
CLS-CLASS	218		Seat/Door	PSD/MSC - Sliding roof control																																	
CLS-CLASS	218		Seat/Door	HKS - Tailgate control																																	
CLS-CLASS	218		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	218		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	218		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	218		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DCM-RR - Door control module rear right		V																		V						V		V					
CLS-CLASS	218		Seat/Door	DCM-RL - Door control module rear left		V																		V		V						V					
CLS-CLASS	218		Seat/Door	DCM-FR - Door control module front right		V																		V						V		V					
CLS-CLASS	218		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
CLS-CLASS	218		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	218		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	215		Drive	ME/CDI/CNG - Engine control unit			V		V	V	V	V	V	V								V															
CL-CLASS	215		Drive	ETC - Electronic transmission control																																	
CL-CLASS	215		Drive	ESM - Electronic selector module																																	
CL-CLASS	215		Drive	DTR - Distronic																																	
CL-CLASS	215		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	215		Chassis	Suspension															V																		
CL-CLASS	215		Chassis	PSE - Pneumatic system equipment																																	
CL-CLASS	215		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	215		Body	UCP - Upper control panel																																	
CL-CLASS	215		Body	System diagnosis																																	
CL-CLASS	215		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	215		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	215		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CL-CLASS	215		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	215		Body	RCM - Rear control module																												V		V	V		
CL-CLASS	215		Body	OCP - Overhead control panel																																	
CL-CLASS	215		Body	Multifunction control unit																																	
CL-CLASS	215		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	215		Body	HSW/LRH - Steering wheel heater																																	
CL-CLASS	215		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	215		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	215		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	215		Body	CGW - Central gateway																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
CL-CLASS	215		Body	AHE - Trailer recognition																																	
CL-CLASS	215		Body	AB - Airbag																																	
CL-CLASS	215		Information	TV - TV tuner																																	
CL-CLASS	215		Information	PTS - Parktronic system																																	
CL-CLASS	215		Information	NAV - Navigation module																																	
CL-CLASS	215		Information	IC - Instrument cluster		V													V	V																	
CL-CLASS	215		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	215		Information	AUDIO/COMAND																																	
CL-CLASS	215		Information	AGW - Audio gateway																																	
CL-CLASS	215		Seat/Door	OSB-FR - Multicontour backrest front right																																	
CL-CLASS	215		Seat/Door	OSB-FL - Multicontour backrest front left																																	
CL-CLASS	215		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	215		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	215		Seat/Door	DCM-FR - Door control module front right																													V				
CL-CLASS	215		Seat/Door	DCM-FL - Door control module front left																													V				
CL-CLASS	215		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	215		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
CL-CLASS	215		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	216		Drive	ME/CDI/CNG - Engine control unit				V	V	V	V	V	V		V	V	V	V																			
CL-CLASS	216		Drive	ETC - Electronic transmission control																																	
CL-CLASS	216		Drive	ISM - Intelligent servo module																																	
CL-CLASS	216		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	216		Drive	DTR - Distronic																																	
CL-CLASS	216		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	216		Chassis	Suspension																																	
CL-CLASS	216		Chassis	ES - Electrical power steering																																	
CL-CLASS	216		Chassis	EFB - Electric parking brake																																	
CL-CLASS	216		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	216		Body	WSS - Weight sensing system																																	
CL-CLASS	216		Body	UCP - Upper control panel																																	
CL-CLASS	216		Body	System diagnosis																																	
CL-CLASS	216		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	216		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	216		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	216		Body	RCM - Rear control module																														V	V		
CL-CLASS	216		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
CL-CLASS	216		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	216		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	216		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	216		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	216		Body	CGW - Central gateway																																	
CL-CLASS	216		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	216		Body	AHE - Trailer recognition																																	
CL-CLASS	216		Body	AB - Airbag																																	
CL-CLASS	216		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	216		Information	VCS - Voice control																																	
CL-CLASS	216		Information	TV - TV tuner																																	
CL-CLASS	216		Information	Tuner - Standard tuner																																	
CL-CLASS	216		Information	SGR - Radar sensors control unit																																	
CL-CLASS	216		Information	MFK - Multifunction camera																																	
CL-CLASS	216		Information	RFK - Backup camera																																	
CL-CLASS	216		Information	PTS - Parktronic system																																	
CL-CLASS	216		Information	NSA - Night View Assist																																	
CL-CLASS	216		Information	NBR-LF - Left front range radar																																	
CL-CLASS	216		Information	NAV - Navigation module																																	
CL-CLASS	216		Information	MIF/UCI - Media interface																																	
CL-CLASS	216		Information	ICI - InCar Internet																																	
CL-CLASS	216		Information	IC - Instrument cluster																																	
CL-CLASS	216		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	216		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	216		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	216		Information	AUDIO/COMAND																																	
CL-CLASS	216		Information	ASSYST PLUS - PLUS Active Service System																																	
CL-CLASS	216		Information	ASSYST Active Service System																																	
CL-CLASS	216		Seat/Door	TLC/GTO - Garage door opener																																	
CL-CLASS	216		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	216		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	216		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	216		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	216		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
CL-CLASS	216		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	216		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	216		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	217		Drive	SCR - Selective catalytic reduction																																	
CL-CLASS	217		Drive	SG-EM - Power electronics																																	
CL-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	217		Drive	DTR - Distronic																																	
CL-CLASS	217		Drive	ISM - Intelligent servo module																																	
CL-CLASS	217		Drive	ME/CDI/CNG - Engine control unit																																	
CL-CLASS	217		Drive	ETC - Electronic transmission control																																	
CL-CLASS	217		Drive	PTCU - Common powertrain controller																																	
CL-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	217		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	217		Chassis	ES - Electrical power steering																																	
CL-CLASS	217		Chassis	Suspension																																	
CL-CLASS	217		Chassis	EFB - Electric parking brake																																	
CL-CLASS	217		Information	TPAD - Touchpad		V																															
CL-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	217		Information	360' - Camera																																	
CL-CLASS	217		Information	SOUND - Sound system																																	
CL-CLASS	217		Information	RFK - Backup camera																																	
CL-CLASS	217		Information	SGR - Radar sensors control unit																																	
CL-CLASS	217		Information	PTS - Parktronic system																																	
CL-CLASS	217		Information	NSA - Night View Assist																																	
CL-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CL-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CL-CLASS	217		Information	NBR-RF - Right front range radar																																	
CL-CLASS	217		Information	NBR-LF - Left front range radar																																	
CL-CLASS	217		Information	MFK - Multifunction camera																																	
CL-CLASS	217		Information	Head-up display																																	
CL-CLASS	217		Information	AUDIO/COMAND																																	
CL-CLASS	217		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	217		Information	KAB - Camera cover																																	
CL-CLASS	217		Information	IC - Instrument cluster																																	
CL-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box		V																															

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
CL-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CL-CLASS	217		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	AB - Airbag																																	
CL-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
CL-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	217		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	217		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
CL-CLASS	217		Seat/Door	DCM-FR - Door control module front right																				V													
CL-CLASS	217		Seat/Door	DCM-FL - Door control module front left																				V													
CL-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
CL-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	170		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V								V															
SLK-CLASS	170		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	170		Drive	ESM - Electronic selector module																																	
SLK-CLASS	170		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	170		Chassis	VP - Vacuum pump brake booster																																	
SLK-CLASS	170		Chassis	BAS - Brake assist																																	
SLK-CLASS	170		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	170		Body	AB - Airbag																																	
SLK-CLASS	170		Information	IC - Instrument cluster																V																	
SLK-CLASS	170		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	170		Information	AUDIO/COMAND																																	
SLK-CLASS	170		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
SLK-CLASS	170		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	171		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V					V														
SLK-CLASS	171		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	171		Drive	ESM - Electronic selector module																																	
SLK-CLASS	171		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	171		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	171		Body	WSS - Weight sensing system																																	
SLK-CLASS	171		Body	UCP - Upper control panel																																	
SLK-CLASS	171		Body	System diagnosis																																	
SLK-CLASS	171		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	171		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	171		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLK-CLASS	171		Body	OCP - Overhead control panel																																	
SLK-CLASS	171		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	171		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	171		Body	CGW - Central gateway																																	
SLK-CLASS	171		Body	AB - Airbag																																	
SLK-CLASS	171		Information	TV - TV tuner																																	
SLK-CLASS	171		Information	SOUND - Sound system																																	
SLK-CLASS	171		Information	PTS - Parktronic system																																	
SLK-CLASS	171		Information	MIF/UCI - Media interface																																	
SLK-CLASS	171		Information	IC - Instrument cluster		V														V																	
SLK-CLASS	171		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	171		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	171		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SLK-CLASS	171		Information	AUDIO/COMAND																																	
SLK-CLASS	171		Information	ASSYST PLUS - PLUS Active Service System																																	
SLK-CLASS	171		Information	ASSYST Active Service System																V																	
SLK-CLASS	171		Information	AGW - Audio gateway																																	
SLK-CLASS	171		Seat/Door	RVC/VDS - Convertible roof control																												V					
SLK-CLASS	171		Seat/Door	HS - Seat heater																																	
SLK-CLASS	171		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	171		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	171		Seat/Door	DCM-FR - Door control module front right																												V	V				
SLK-CLASS	171		Seat/Door	DCM-FL - Door control module front left																												V	V				
SLK-CLASS	171		Air Conditioning	AAC - Automatic air conditioning																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
SLK-CLASS	172		Drive	ME/CDI/CNG - Engine control unit																																	
SLK-CLASS	172		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	172		Drive	ESM - Electronic selector module																																	
SLK-CLASS	172		Drive	DTR - Distronic																																	
SLK-CLASS	172		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLK-CLASS	172		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	172		Chassis	Suspension																																	
SLK-CLASS	172		Chassis	ES - Electrical power steering																																	
SLK-CLASS	172		Chassis	EFB - Electric parking brake																																	
SLK-CLASS	172		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	172		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	172		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	172		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
SLK-CLASS	172		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	172		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLK-CLASS	172		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	172		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	172		Body	CGW - Central gateway																																	
SLK-CLASS	172		Body	AB - Airbag																																	
SLK-CLASS	172		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SLK-CLASS	172		Information	ZAN - Audio/COMAND display																																	
SLK-CLASS	172		Information	TV - TV tuner																																	
SLK-CLASS	172		Information	SOUND - Sound system																																	
SLK-CLASS	172		Information	SGR - Radar sensors control unit																																	
SLK-CLASS	172		Information	MFK - Multifunction camera																																	
SLK-CLASS	172		Information	PTS - Parktronic system																																	
SLK-CLASS	172		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLK-CLASS	172		Information	NBR-RF - Right front range radar																																	
SLK-CLASS	172		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLK-CLASS	172		Information	NBR-LF - Left front range radar																																	
SLK-CLASS	172		Information	NAV - Navigation module																																	
SLK-CLASS	172		Information	MIF/UCI - Media interface																																	
SLK-CLASS	172		Information	IC - Instrument cluster																																	
SLK-CLASS	172		Information	DTA - Mbrace or TELEAID/GPS Box		V																															

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
SLK-CLASS	172		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	172		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLK-CLASS	172		Information	AUDIO/COMAND																																	
SLK-CLASS	172		Seat/Door	RVC/VDS - Convertible roof control																						V				V							
SLK-CLASS	172		Seat/Door	PSD/MSC - Sliding roof control																																	
SLK-CLASS	172		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	172		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	172		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
SLK-CLASS	172		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
SLK-CLASS	172		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	129		Drive	ME/CDI/CNG - Engine control unit																		V															
SL-CLASS	129		Drive	ETC - Electronic transmission control																																	
SL-CLASS	129		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	129		Chassis	BAS - Brake assist																																	
SL-CLASS	129		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	129		Body	AB - Airbag																																	
SL-CLASS	129		Information	NAV - Navigation module																																	
SL-CLASS	129		Information	IC - Instrument cluster		V														V	V																
SL-CLASS	129		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	129		Information	AUDIO/COMAND																																	
SL-CLASS	129		Information	APS - Auto pilot system																																	
SL-CLASS	129		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	129		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	230		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V				V															
SL-CLASS	230		Drive	ETC - Electronic transmission control																																	
SL-CLASS	230		Drive	ESM - Electronic selector module																																	
SL-CLASS	230		Drive	DTR - Distronic																																	
SL-CLASS	230		Drive	AMG DRIVE UNIT																																	
SL-CLASS	230		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	230		Chassis	Suspension															V																		
SL-CLASS	230		Chassis	SBC - Sensotronic Brake Control																		V															
SL-CLASS	230		Chassis	PSE - Pneumatic system equipment																																	
SL-CLASS	230		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	230		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	230		Body	WSS - Weight sensing system																																	
SL-CLASS	230		Body	System diagnosis																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
SL-CLASS	230		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	230		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	230		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SL-CLASS	230		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	230		Body	OCP - Overhead control panel																																	
SL-CLASS	230		Body	LCP/HBF - Lower/Rear control panel																																	
SL-CLASS	230		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	230		Body	HSW/LRH - Steering wheel heater																																	
SL-CLASS	230		Body	Headlamp-R - Headlamp control unit																																	
SL-CLASS	230		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	230		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	230		Body	CGW - Central gateway																																	
SL-CLASS	230		Body	BNS/BMS - Battery sensor																																	
SL-CLASS	230		Body	AB - Airbag																																	
SL-CLASS	230		Information	TV - TV tuner																																	
SL-CLASS	230		Information	SOUND - Sound system																																	
SL-CLASS	230		Information	PTS - Parktronic system																																	
SL-CLASS	230		Information	MIF/UCI - Media interface																																	
SL-CLASS	230		Information	IC - Instrument cluster		V														V																	
SL-CLASS	230		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	230		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	230		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SL-CLASS	230		Information	AUDIO/COMAND																																	
SL-CLASS	230		Information	AGW - Audio gateway																																	
SL-CLASS	230		Seat/Door	RVC/VDS - Convertible roof control																								V									
SL-CLASS	230		Seat/Door	OSB-FR - Multicontour backrest front right																																	
SL-CLASS	230		Seat/Door	OSB-FL - Multicontour backrest front left																																	
SL-CLASS	230		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	230		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	230		Seat/Door	DCM-FR - Door control module front right																													V				
SL-CLASS	230		Seat/Door	DCM-FL - Door control module front left																													V				
SL-CLASS	230		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	230		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	231		Drive	ME/CDI/CNG - Engine control unit																																	
SL-CLASS	231		Drive	ETC - Electronic transmission control																																	
SL-CLASS	231		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
SL-CLASS	231		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SL-CLASS	231		Drive	DTR - Distronic																																	
SL-CLASS	231		Drive	DSI - Direct select interface																																	
SL-CLASS	231		Drive	AMG DRIVE UNIT																																	
SL-CLASS	231		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	231		Chassis	Suspension																																	
SL-CLASS	231		Chassis	ES - Electrical power steering																																	
SL-CLASS	231		Chassis	EFB - Electric parking brake																																	
SL-CLASS	231		Chassis	FWGW - Chassis gateway																																	
SL-CLASS	231		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	231		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	231		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	231		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
SL-CLASS	231		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	231		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	231		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	231		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	231		Body	CGW - Central gateway																																	
SL-CLASS	231		Body	AB - Airbag																																	
SL-CLASS	231		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SL-CLASS	231		Information	ZAN - Audio/COMAND display																																	
SL-CLASS	231		Information	TV - TV tuner																																	
SL-CLASS	231		Information	SOUND - Sound system																																	
SL-CLASS	231		Information	SGR - Radar sensors control unit																																	
SL-CLASS	231		Information	RFK - Backup camera																																	
SL-CLASS	231		Information	MFK - Multifunction camera																																	
SL-CLASS	231		Information	PTS - Parktronic system																																	
SL-CLASS	231		Information	NSA - Night View Assist																																	
SL-CLASS	231		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SL-CLASS	231		Information	NBR-RF - Right front range radar																																	
SL-CLASS	231		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SL-CLASS	231		Information	NBR-LF - Left front range radar																																	
SL-CLASS	231		Information	MIF/UCI - Media interface																																	
SL-CLASS	231		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
SL-CLASS	231		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
SL-CLASS	231		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	231		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SL-CLASS	231		Information	AUDIO/COMAND																																	
SL-CLASS	231		Information	AMG Performance Media																																	
SL-CLASS	231		Seat/Door	RVC/VDS - Convertible roof control																						V				V							
SL-CLASS	231		Seat/Door	PSD/MSC - Sliding roof control																																	
SL-CLASS	231		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	231		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	231		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
SL-CLASS	231		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
SL-CLASS	231		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
SL-CLASS	231		Air Conditioning	AAC - Automatic air conditioning																																	
SLS-CLASS	197		Drive	PTCU - Common powertrain controller																																	
SLS-CLASS	197		Drive	ME/CDI/CNG - Engine control unit				V	V	V	V	V	V		V	V	V	V																			
SLS-CLASS	197		Drive	ETC - Electronic transmission control																																	
SLS-CLASS	197		Drive	ISM - Intelligent servo module																																	
SLS-CLASS	197		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLS-CLASS	197		Drive	DSI - Direct select interface																																	
SLS-CLASS	197		Drive	AMG DRIVE UNIT																																	
SLS-CLASS	197		Chassis	ABS/ESP - Electronic stability program																																	
SLS-CLASS	197		Chassis	Suspension																																	
SLS-CLASS	197		Chassis	ES - Electrical power steering																																	
SLS-CLASS	197		Chassis	EFB - Electric parking brake																																	
SLS-CLASS	197		Chassis	TPM - Tire pressure monitor																																	
SLS-CLASS	197		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	CSHV - Crash sensor/high-voltage battery																																	
SLS-CLASS	197		Body	BNS/BMS - Battery sensor																																	
SLS-CLASS	197		Body	WSS - Weight sensing system																																	
SLS-CLASS	197		Body	SCM [MRM] - Steering column module																																	
SLS-CLASS	197		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLS-CLASS	197		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
SLS-CLASS	197		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
SLS-CLASS	197		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLS-CLASS	197		Body	EZS/EIS - Electronic ignition lock																																	
SLS-CLASS	197		Body	CGW - Central gateway																																	
SLS-CLASS	197		Body	AB - Airbag																																	
SLS-CLASS	197		Information	MFK - Multifunction camera																																	
SLS-CLASS	197		Information	SGR - Radar sensors control unit																																	
SLS-CLASS	197		Information	ZAN - Audio/COMAND display																																	
SLS-CLASS	197		Information	SOUND - Sound system																																	
SLS-CLASS	197		Information	PTS - Parktronic system																																	
SLS-CLASS	197		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLS-CLASS	197		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLS-CLASS	197		Information	MIF/UCI - Media interface																																	
SLS-CLASS	197		Information	IC - Instrument cluster																																	
SLS-CLASS	197		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLS-CLASS	197		Information	DAB/SDAR - Digital/Satellite radio																																	
SLS-CLASS	197		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLS-CLASS	197		Information	AUDIO/COMAND																																	
SLS-CLASS	197		Information	AMG Performance Media																																	
SLS-CLASS	197		Seat/Door	RVC/VDS - Convertible roof control																						V				V							
SLS-CLASS	197		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLS-CLASS	197		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLS-CLASS	197		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
SLS-CLASS	197		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
SLS-CLASS	197		Air Conditioning	AAC - Automatic air conditioning																																	
AMG GT	190		Drive	DTR - Distronic																																	
AMG GT	190		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
AMG GT	190		Drive	DSI - Direct select interface																																	
AMG GT	190		Drive	AMG DRIVE UNIT																																	
AMG GT	190		Drive	PTCU - Common powertrain controller																																	
AMG GT	190		Drive	ME/CDI/CNG - Engine control unit																																	
AMG GT	190		Drive	ETC - Electronic transmission control																																	
AMG GT	190		Chassis	TPM - Tire pressure monitor																																	
AMG GT	190		Chassis	Suspension																																	
AMG GT	190		Chassis	ABS/ESP - Electronic stability program																																	
AMG GT	190		Chassis	EFB - Electric parking brake																																	
AMG GT	190		Information	TPAD - Touchpad		V																															

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
AMG GT	190		Information	DAB/SDAR - Digital/Satellite radio																																	
AMG GT	190		Information	SOUND - Sound system																																	
AMG GT	190		Information	RFK - Backup camera																																	
AMG GT	190		Information	PTS - Parktronic system																																	
AMG GT	190		Information	MFK - Multifunction camera																																	
AMG GT	190		Information	IC - Instrument cluster																																	
AMG GT	190		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
AMG GT	190		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
AMG GT	190		Information	AUDIO/COMAND																																	
AMG GT	190		Information	ZAN - Audio/COMAND display																																	
AMG GT	190		Information	COU [ZBE] - Audio/COMAND operating unit																																	
AMG GT	190		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
AMG GT	190		Information	AMG Performance Media																																	
AMG GT	190		Body	SCM [MRM] - Steering column module																																	
AMG GT	190		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
AMG GT	190		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
AMG GT	190		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
AMG GT	190		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
AMG GT	190		Body	AB - Airbag																																	
AMG GT	190		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
AMG GT	190		Body	Headlamp-R - Headlamp control unit																																	
AMG GT	190		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
AMG GT	190		Body	SG-AWF - Collision prevention assist																																	
AMG GT	190		Body	EZS/EIS - Electronic ignition lock																																	
AMG GT	190		Body	CGW - Central gateway																																	
AMG GT	190		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
AMG GT	190		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
AMG GT	190		Seat/Door	DCM-FR - Door control module front right		V																		V					V			V					
AMG GT	190		Seat/Door	DCM-FL - Door control module front left		V																		V	V							V					
AMG GT	190		Air Conditioning	AAC - Automatic air conditioning																																	
SLR-CLASS	199		Drive	ME/CDI/CNG - Engine control unit			V		V	V	V	V	V	V								V															
SLR-CLASS	199		Drive	ETC - Electronic transmission control																																	
SLR-CLASS	199		Drive	ESM - Electronic selector module																																	
SLR-CLASS	199		Chassis	ABS/ESP - Electronic stability program																																	
SLR-CLASS	199		Chassis	SBC - Sensotronic Brake Control																		V															
SLR-CLASS	199		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
SLR-CLASS	199		Body	WSS - Weight sensing system																																	
SLR-CLASS	199		Body	SCM [MRM] - Steering column module																																	
SLR-CLASS	199		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLR-CLASS	199		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SLR-CLASS	199		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLR-CLASS	199		Body	OCP - Overhead control panel																																	
SLR-CLASS	199		Body	LCP/HBF - Lower/Rear control panel																																	
SLR-CLASS	199		Body	Headlamp-R - Headlamp control unit																																	
SLR-CLASS	199		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLR-CLASS	199		Body	EZS/EIS - Electronic ignition lock																																	
SLR-CLASS	199		Body	CGW - Central gateway																																	
SLR-CLASS	199		Body	BNS/BMS - Battery sensor																																	
SLR-CLASS	199		Body	AB - Airbag																																	
SLR-CLASS	199		Information	IC - Instrument cluster		V														V																	
SLR-CLASS	199		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLR-CLASS	199		Information	AUDIO/COMAND																																	
SLR-CLASS	199		Seat/Door	DCM-FR - Door control module front right																													V				
SLR-CLASS	199		Seat/Door	DCM-FL - Door control module front left																													V				
SLR-CLASS	199		Air Conditioning	AAC - Automatic air conditioning																																	
MAYBACH	240		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V				V															
MAYBACH	240		Drive	ETC - Electronic transmission control																																	
MAYBACH	240		Drive	ESM - Electronic selector module																																	
MAYBACH	240		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
MAYBACH	240		Drive	DTR - Distronic																																	
MAYBACH	240		Chassis	ABS/ESP - Electronic stability program																																	
MAYBACH	240		Chassis	Suspension																																	
MAYBACH	240		Chassis	SBC - Sensotronic Brake Control																		V															
MAYBACH	240		Chassis	TPM - Tire pressure monitor																																	
MAYBACH	240		Body	WSS - Weight sensing system																																	
MAYBACH	240		Body	System diagnosis																																	
MAYBACH	240		Body	SCM [MRM] - Steering column module																																	
MAYBACH	240		Body	HSW/LRH - Steering wheel heater																																	
MAYBACH	240		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
MAYBACH	240		Body	AB - Airbag																																	
MAYBACH	240		Information	TV - TV tuner																																	
MAYBACH	240		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
MAYBACH	240		Information	DTA - Mbrace or TELEAID/GPS Box																																	
MAYBACH	240		Information	AGW - Audio gateway																																	
MAYBACH	240		Seat/Door	REDC/RWT - Rear end door control module																								V				V					
MAYBACH	240		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All_Model(BETA)	16P Connector		Drive	SG-EM - Power electronics																																	
All_Model(BETA)	16P Connector		Drive	HFPM - Haptic accelerator pedal module																																	
All_Model(BETA)	16P Connector		Drive	ME/CDI/CNG - Engine control unit			V	V	V	V	V	V	V	V	V	V	V	V					V														
All_Model(BETA)	16P Connector		Drive	ETC - Electronic transmission control																																	
All_Model(BETA)	16P Connector		Drive	ESM - Electronic selector module																																	
All_Model(BETA)	16P Connector		Drive	VG - Transfer case																																	
All_Model(BETA)	16P Connector		Drive	VECU - Power monitoring control unit																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-B - Electric motor control unit B																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-A - Electric motor control unit A																																	
All_Model(BETA)	16P Connector		Drive	SCR - Selective catalytic reduction																																	
All_Model(BETA)	16P Connector		Drive	PTCU - Common powertrain controller																																	
All_Model(BETA)	16P Connector		Drive	Natural gas control unit																																	
All_Model(BETA)	16P Connector		Drive	ISM - Intelligent servo module																																	
All_Model(BETA)	16P Connector		Drive	Hydrogen tank control unit																																	
All_Model(BETA)	16P Connector		Drive	HSG - Hybrid control unit																																	
All_Model(BETA)	16P Connector		Drive	High-temperature coolant pump control unit																																	
All_Model(BETA)	16P Connector		Drive	Fuel cell control unit																																	
All_Model(BETA)	16P Connector		Drive	FSCU-R - Control unit fuel pump																																	
All_Model(BETA)	16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
All_Model(BETA)	16P Connector		Drive	EMPI - Electronic Motor Pump Inverter																																	
All_Model(BETA)	16P Connector		Drive	Electric drive control unit																																	
All_Model(BETA)	16P Connector		Drive	DTR - Distronic																																	
All_Model(BETA)	16P Connector		Drive	DSI - Direct select interface																																	
All_Model(BETA)	16P Connector		Drive	Compressed Natural Gas Control Module																																	
All_Model(BETA)	16P Connector		Drive	CC - Cruise control																																	
All_Model(BETA)	16P Connector		Drive	BSA - Belt-driven starter/alternator																																	
All_Model(BETA)	16P Connector		Drive	AMG DRIVE UNIT																																	
All_Model(BETA)	16P Connector		Drive	ACS - Automatic clutch system																																	
All_Model(BETA)	16P Connector		Chassis	ABS/ESP - Electronic stability program																																	
All_Model(BETA)	16P Connector		Chassis	Suspension															V																		
All_Model(BETA)	16P Connector		Chassis	SBC - Sensotronic Brake Control																		V															
All_Model(BETA)	16P Connector		Chassis	PSE - Pneumatic system equipment																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
All_Model(BETA)	16P Connector		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
All_Model(BETA)	16P Connector		Chassis	HAQ - Interwheel differential lock at rear axle																																	
All_Model(BETA)	16P Connector		Chassis	FWGW - Chassis gateway																																	
All_Model(BETA)	16P Connector		Chassis	ES - Electrical power steering																																	
All_Model(BETA)	16P Connector		Chassis	EFB - Electric parking brake																																	
All_Model(BETA)	16P Connector		Chassis	BAS - Brake assist																																	
All_Model(BETA)	16P Connector		Chassis	VP - Vacuum pump brake booster																																	
All_Model(BETA)	16P Connector		Chassis	TPM - Tire pressure monitor																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
All_Model(BETA)	16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
All_Model(BETA)	16P Connector		Body	CSHV - Crash sensor/high-voltage battery																																	
All_Model(BETA)	16P Connector		Body	WSS - Weight sensing system																																	
All_Model(BETA)	16P Connector		Body	UCP - Upper control panel																																	
All_Model(BETA)	16P Connector		Body	System diagnosis																																	
All_Model(BETA)	16P Connector		Body	SG-DDW - DC/DC converter control unit																																	
All_Model(BETA)	16P Connector		Body	SG-AWF - Collision prevention assist																																	
All_Model(BETA)	16P Connector		Body	SCM [MRM] - Steering column module																																	
All_Model(BETA)	16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
All_Model(BETA)	16P Connector		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
All_Model(BETA)	16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																						V				V							
All_Model(BETA)	16P Connector		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
All_Model(BETA)	16P Connector		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
All_Model(BETA)	16P Connector		Body	RCM - Rear control module																												V	V	V	V		
All_Model(BETA)	16P Connector		Body	OCP - Overhead control panel																																	
All_Model(BETA)	16P Connector		Body	Multifunction control unit																																	
All_Model(BETA)	16P Connector		Body	LCP/HBF - Lower/Rear control panel																																	
All_Model(BETA)	16P Connector		Body	LAE [LAA] - Loading floor automatically extendable																																	
All_Model(BETA)	16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
All_Model(BETA)	16P Connector		Body	HSW/LRH - Steering wheel heater																																	
All_Model(BETA)	16P Connector		Body	Headlamp-R - Headlamp control unit																																	
All_Model(BETA)	16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
All_Model(BETA)	16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
All_Model(BETA)	16P Connector		Body	CGW - Central gateway																																	
All_Model(BETA)	16P Connector		Body	BNS/BMS - Battery sensor																																	
All_Model(BETA)	16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
All_Model(BETA)	16P Connector		Body	AHE - Trailer recognition																																	
All_Model(BETA)	16P Connector		Body	AB - Airbag																																	
All_Model(BETA)	16P Connector		Body	AAM - All activity module																																	
All_Model(BETA)	16P Connector		Information	TPAD - Touchpad		V																															
All_Model(BETA)	16P Connector		Information	Head-up display																																	
All_Model(BETA)	16P Connector		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
All_Model(BETA)	16P Connector		Information	KAB - Camera cover																																	
All_Model(BETA)	16P Connector		Information	ZAN - Audio/COMAND display																																	
All_Model(BETA)	16P Connector		Information	VCS - Voice control																																	
All_Model(BETA)	16P Connector		Information	TV - TV tuner																																	
All_Model(BETA)	16P Connector		Information	Tuner - Standard tuner																																	
All_Model(BETA)	16P Connector		Information	Sound generator for exhaust system																																	
All_Model(BETA)	16P Connector		Information	SOUND - Sound system																																	
All_Model(BETA)	16P Connector		Information	SGR - Radar sensors control unit																																	
All_Model(BETA)	16P Connector		Information	360' - Camera																																	
All_Model(BETA)	16P Connector		Information	MFK - Multifunction camera																																	
All_Model(BETA)	16P Connector		Information	RFK - Backup camera																																	
All_Model(BETA)	16P Connector		Information	PTS - Parktronic system																																	
All_Model(BETA)	16P Connector		Information	NSA - Night View Assist																																	
All_Model(BETA)	16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-RF - Right front range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LF - Left front range radar																																	
All_Model(BETA)	16P Connector		Information	NAV - Navigation module																																	
All_Model(BETA)	16P Connector		Information	MIF/UCI - Media interface																																	
All_Model(BETA)	16P Connector		Information	ICI - InCar Internet																																	
All_Model(BETA)	16P Connector		Information	IC - Instrument cluster		V													V	V																	
All_Model(BETA)	16P Connector		Information	DVD player																																	
All_Model(BETA)	16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box		V																															
All_Model(BETA)	16P Connector		Information	D-FOR - Display in right rear passenger																																	
All_Model(BETA)	16P Connector		Information	D-FOL - Display in left rear passenger																																	
All_Model(BETA)	16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
All_Model(BETA)	16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
All_Model(BETA)	16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
All_Model(BETA)	16P Connector		Information	CM - Compass module																																	
All_Model(BETA)	16P Connector		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing
All Model(BETA)	16P Connector		Information	AUDIO/COMAND																																	
All Model(BETA)	16P Connector		Information	ASSYST PLUS - PLUS Active Service System																																	
All Model(BETA)	16P Connector		Information	ASSYST Active Service System																	V																
All Model(BETA)	16P Connector		Information	APS - Auto pilot system																																	
All Model(BETA)	16P Connector		Information	AMG Performance Media																																	
All Model(BETA)	16P Connector		Information	AGW - Audio gateway																																	
All Model(BETA)	16P Connector		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-MR - Right center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-ML - Left center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TLC/GTO - Garage door opener																																	
All Model(BETA)	16P Connector		Seat/Door	RVC/VDS - Convertible roof control																						V		V		V							
All Model(BETA)	16P Connector		Seat/Door	REDC/RWT - Rear end door control module																							V				V						
All Model(BETA)	16P Connector		Seat/Door	PSD/MSC - Sliding roof control																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-R - Multicontour backrest rear																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FR - Multicontour backrest front right																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FL - Multicontour backrest front left																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	HS - Seat heater																																	
All Model(BETA)	16P Connector		Seat/Door	HKS - Tailgate control																																	
All Model(BETA)	16P Connector		Seat/Door	ESA-R - Electric seat adjustment rear																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
All Model(BETA)	16P Connector		Seat/Door	ERA - Electric fold down backrest system																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-RR - Door control module rear right		V																		V	V						V		V					
All Model(BETA)	16P Connector		Seat/Door	DCM-RL - Door control module rear left		V																		V	V		V						V					
All Model(BETA)	16P Connector		Seat/Door	DCM-FR - Door control module front right		V																		V	V					V			V	V				
All Model(BETA)	16P Connector		Seat/Door	DCM-FL - Door control module front left		V																		V	V	V							V	V				
All Model(BETA)	16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All Model(BETA)	16P Connector		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
All Model(BETA)	16P Connector		Air Conditioning	HBF - Rear control panel																																	
All Model(BETA)	16P Connector		Air Conditioning	HB - Heater booster																																	
All Model(BETA)	16P Connector		Air Conditioning	EKMK - Electric refrigerant compressor																																	
All Model(BETA)	16P Connector		Air Conditioning	AAC - Automatic air conditioning																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
A-CLASS	68		Drive	ME/CDI/CNG - Engine control unit											V																						
A-CLASS	68		Drive	ETC - Electronic transmission control													V													V							
A-CLASS	68		Drive	ESM - Electronic selector module																																	
A-CLASS	68		Drive	ACS - Automatic clutch system																																	
A-CLASS	68		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Body	LCP/HBF - Lower/Rear control panel																																	
A-CLASS	168		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	168		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	168		Body	AB - Airbag																																	
A-CLASS	168		Information	PTS - Parktronic system																																	
A-CLASS	168		Information	IC - Instrument cluster																V																	
A-CLASS	168		Information	AUDIO/COMAND																																	
A-CLASS	168		Information	APS - Auto pilot system																																	
A-CLASS	168		Seat/Door	DCM-RR - Door control module rear right																																	
A-CLASS	168		Seat/Door	DCM-RL - Door control module rear left																																	
A-CLASS	168		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	168		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	168		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	168		Air Conditioning	HB - Heater booster																																	
A-CLASS	168		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	169		Drive	ME/CDI/CNG - Engine control unit							V																				V		V	V			
A-CLASS	169		Drive	ETC - Electronic transmission control																																	
A-CLASS	169		Drive	ESM - Electronic selector module																																	
A-CLASS	169		Drive	BSA - Belt-driven starter/alternator																																	
A-CLASS	169		Chassis	ABS/ESP - Electronic stability program																			V		V												
A-CLASS	169		Chassis	ES - Electrical power steering																																	
A-CLASS	169		Body	SCM [MRM] - Steering column module																																	
A-CLASS	169		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V																													
A-CLASS	169		Body	OCP - Overhead control panel																																	
A-CLASS	169		Body	Multifunction control unit																																	
A-CLASS	169		Body	Headlamp-R - Headlamp control unit																																	
A-CLASS	169		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
A-CLASS	169		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	169		Body	CGW - Central gateway																																	
A-CLASS	169		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
A-CLASS	169		Body	AHE - Trailer recognition																																	
A-CLASS	169		Body	AB - Airbag																																	
A-CLASS	169		Information	SOUND - Sound system																																	
A-CLASS	169		Information	PTS - Parktronic system																																	
A-CLASS	169		Information	MIF/UCI - Media interface																																	
A-CLASS	169		Information	IC - Instrument cluster						V																											
A-CLASS	169		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	169		Information	CTEL/TEL - Cellular/Mobile telephone																																	
A-CLASS	169		Information	AUDIO/COMAND																																	
A-CLASS	169		Information	ASSYST PLUS - PLUS Active Service System																																	
A-CLASS	169		Information	ASSYST Active Service System						V																											
A-CLASS	169		Information	AGW - Audio gateway																																	
A-CLASS	169		Seat/Door	DCM-RR - Door control module rear right				V																													
A-CLASS	169		Seat/Door	DCM-RL - Door control module rear left		V																															
A-CLASS	169		Seat/Door	DCM-FR - Door control module front right			V																														
A-CLASS	169		Seat/Door	DCM-FL - Door control module front left	V																																
A-CLASS	169		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	176		Drive	VG - Transfer case																																	
A-CLASS	176		Drive	ME/CDI/CNG - Engine control unit							V																						V				
A-CLASS	176		Drive	ETC - Electronic transmission control																																	
A-CLASS	176		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
A-CLASS	176		Drive	DTR - Distronic																																	
A-CLASS	176		Drive	DSI - Direct select interface																																	
A-CLASS	176		Drive	PTCU - Common powertrain controller																																	
A-CLASS	176		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	176		Chassis	ES - Electrical power steering																																	
A-CLASS	176		Chassis	EFB - Electric parking brake										V																							
A-CLASS	176		Chassis	TPM - Tire pressure monitor																																	
A-CLASS	176		Body	SG-AWF - Collision prevention assist																																	
A-CLASS	176		Body	SCM [MRM] - Steering column module																																	
A-CLASS	176		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
A-CLASS	176		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
A-CLASS	176		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
A-CLASS	176		Body	Multifunction control unit																																	
A-CLASS	176		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
A-CLASS	176		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
A-CLASS	176		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	176		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	176		Body	AHE - Trailer recognition																																	
A-CLASS	176		Body	AB - Airbag																																	
A-CLASS	176		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
A-CLASS	176		Information	ZAN - Audio/COMAND display																																	
A-CLASS	176		Information	TV - TV tuner																																	
A-CLASS	176		Information	SOUND - Sound system																																	
A-CLASS	176		Information	RFK - Backup camera																																	
A-CLASS	176		Information	MFK - Multifunction camera																																	
A-CLASS	176		Information	PTS - Parktronic system																																	
A-CLASS	176		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
A-CLASS	176		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
A-CLASS	176		Information	NAV - Navigation module																																	
A-CLASS	176		Information	MIF/UCI - Media interface																																	
A-CLASS	176		Information	IC - Instrument cluster																																	
A-CLASS	176		Information	DTA - Mbrace or TELEAID/GPS Box																																	
A-CLASS	176		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	176		Information	COU [ZBE] - Audio/COMAND operating unit																																	
A-CLASS	176		Information	AUDIO/COMAND												V						V															
A-CLASS	176		Seat/Door	PSD/MSC - Sliding roof control																																	
A-CLASS	176		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
A-CLASS	176		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
A-CLASS	176		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	176		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	176		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	176		Air Conditioning	AAC - Automatic air conditioning																																	
B-CLASS	245		Drive	ME/CDI/CNG - Engine control unit																											V		V	V			
B-CLASS	245		Drive	ETC - Electronic transmission control																																	
B-CLASS	245		Drive	ESM - Electronic selector module																																	
B-CLASS	245		Drive	Hydrogen tank control unit																																	
B-CLASS	245		Drive	High-temperature coolant pump control unit																																	
B-CLASS	245		Drive	Fuel cell control unit																																	
B-CLASS	245		Drive	Electric drive control unit																																	
B-CLASS	245		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	245		Drive	BSA - Belt-driven starter/alternator																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
B-CLASS	245		Drive	VECU - Power monitoring control unit																																	
B-CLASS	245		Chassis	ABS/ESP - Electronic stability program																			V		V												
B-CLASS	245		Chassis	ES - Electrical power steering																																	
B-CLASS	245		Chassis	VP - Vacuum pump brake booster																																	
B-CLASS	245		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	245		Body	WSS - Weight sensing system					V																												
B-CLASS	245		Body	SG-DDW - DC/DC converter control unit																																	
B-CLASS	245		Body	SCM [MRM] - Steering column module																																	
B-CLASS	245		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V																													
B-CLASS	245		Body	OCP - Overhead control panel																																	
B-CLASS	245		Body	Multifunction control unit																																	
B-CLASS	245		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	245		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	245		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	245		Body	CGW - Central gateway																																	
B-CLASS	245		Body	BNS/BMS - Battery sensor																																	
B-CLASS	245		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	245		Body	AHE - Trailer recognition																																	
B-CLASS	245		Body	AB - Airbag																																	
B-CLASS	245		Information	SOUND - Sound system																																	
B-CLASS	245		Information	PTS - Parktronic system																																	
B-CLASS	245		Information	NAV - Navigation module																																	
B-CLASS	245		Information	MIF/UCI - Media interface																																	
B-CLASS	245		Information	IC - Instrument cluster						V																											
B-CLASS	245		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	245		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	245		Information	CTEL/TEL - Cellular/Mobile telephone																																	
B-CLASS	245		Information	CM - Compass module																																	
B-CLASS	245		Information	AUDIO/COMAND																																	
B-CLASS	245		Information	ASSYST PLUS - PLUS Active Service System																																	
B-CLASS	245		Information	ASSYST Active Service System						V																											
B-CLASS	245		Information	AGW - Audio gateway																																	
B-CLASS	245		Seat/Door	DCM-RR - Door control module rear right				V																													
B-CLASS	245		Seat/Door	DCM-RL - Door control module rear left		V																															
B-CLASS	245		Seat/Door	DCM-FR - Door control module front right			V																														
B-CLASS	245		Seat/Door	DCM-FL - Door control module front left	V																																

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
B-CLASS	245		Air Conditioning	EKMK - Electric refrigerant compressor																																	
B-CLASS	245		Air Conditioning	AAC - Automatic air conditioning																																	
B-CLASS	246		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	246		Drive	VG - Transfer case																																	
B-CLASS	246		Drive	ME/CDI/CNG - Engine control unit							V																						V				
B-CLASS	246		Drive	ETC - Electronic transmission control																																	
B-CLASS	246		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
B-CLASS	246		Drive	DTR - Distronic																																	
B-CLASS	246		Drive	PTCU - Common powertrain controller																																	
B-CLASS	246		Chassis	ABS/ESP - Electronic stability program																																	
B-CLASS	246		Chassis	ES - Electrical power steering																																	
B-CLASS	246		Chassis	EFB - Electric parking brake										V																							
B-CLASS	246		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	246		Body	BNS/BMS - Battery sensor																																	
B-CLASS	246		Body	SG-AWF - Collision prevention assist																																	
B-CLASS	246		Body	SCM [MRM] - Steering column module																																	
B-CLASS	246		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
B-CLASS	246		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
B-CLASS	246		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
B-CLASS	246		Body	Multifunction control unit																																	
B-CLASS	246		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
B-CLASS	246		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	246		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	246		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	246		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	246		Body	AHE - Trailer recognition																																	
B-CLASS	246		Body	AB - Airbag																																	
B-CLASS	246		Information	Sound generator for exhaust system																																	
B-CLASS	246		Information	Head-up display																																	
B-CLASS	246		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
B-CLASS	246		Information	ZAN - Audio/COMAND display																																	
B-CLASS	246		Information	TV - TV tuner																																	
B-CLASS	246		Information	SOUND - Sound system																																	
B-CLASS	246		Information	RFK - Backup camera																																	
B-CLASS	246		Information	MFK - Multifunction camera																																	
B-CLASS	246		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
B-CLASS	246		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
B-CLASS	246		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
B-CLASS	246		Information	NAV - Navigation module																																	
B-CLASS	246		Information	MIF/UCI - Media interface																																	
B-CLASS	246		Information	IC - Instrument cluster																																	
B-CLASS	246		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	246		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	246		Information	COU [ZBE] - Audio/COMAND operating unit																																	
B-CLASS	246		Information	AUDIO/COMAND												V						V															
B-CLASS	246		Seat/Door	PSD/MSC - Sliding roof control																																	
B-CLASS	246		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
B-CLASS	246		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
B-CLASS	246		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	246		Seat/Door	DCM-FL - Door control module front left																																	
B-CLASS	246		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
B-CLASS	246		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	202		Drive	ME/CDI/CNG - Engine control unit											V																						
C-CLASS	202		Drive	ETC - Electronic transmission control								V					V													V							
C-CLASS	202		Drive	ESM - Electronic selector module																																	
C-CLASS	202		Chassis	PSE - Pneumatic system equipment																																	
C-CLASS	202		Chassis	ABS/ESP - Electronic stability program																					V												
C-CLASS	202		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	202		Chassis	BAS - Brake assist																																	
C-CLASS	202		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	202		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	202		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	202		Body	OCP - Overhead control panel																																	
C-CLASS	202		Body	AB - Airbag																																	
C-CLASS	202		Information	PTS - Parktronic system																																	
C-CLASS	202		Information	NAV - Navigation module																																	
C-CLASS	202		Information	IC - Instrument cluster																V																	
C-CLASS	202		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	202		Information	AUDIO/COMAND																																	
C-CLASS	202		Information	APS - Auto pilot system																																	
C-CLASS	202		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	202		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
C-CLASS	202		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	202		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	202		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	202		Air Conditioning	HB - Heater booster																																	
C-CLASS	202		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	203		Drive	ME/CDI/CNG - Engine control unit									V																	V		V	V	V		
C-CLASS	203		Drive	ETC - Electronic transmission control								V					V												V								
C-CLASS	203		Drive	ESM - Electronic selector module																																	
C-CLASS	203		Drive	DTR - Distronic																																	
C-CLASS	203		Chassis	ABS/ESP - Electronic stability program																			V		V												
C-CLASS	203		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	203		Chassis	BAS - Brake assist																																	
C-CLASS	203		Body	WSS - Weight sensing system					V																												
C-CLASS	203		Body	UCP - Upper control panel																																	
C-CLASS	203		Body	System diagnosis																																	
C-CLASS	203		Body	SCM [MRM] - Steering column module																																	
C-CLASS	203		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	203		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V																													
C-CLASS	203		Body	OCP - Overhead control panel																																	
C-CLASS	203		Body	Multifunction control unit																																	
C-CLASS	203		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	203		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	203		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	203		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	203		Body	CGW - Central gateway																																	
C-CLASS	203		Body	AHE - Trailer recognition																																	
C-CLASS	203		Body	AB - Airbag																																	
C-CLASS	203		Information	TV - TV tuner																																	
C-CLASS	203		Information	SOUND - Sound system																																	
C-CLASS	203		Information	PTS - Parktronic system																																	
C-CLASS	203		Information	NAV - Navigation module																																	
C-CLASS	203		Information	MIF/UCI - Media interface																																	
C-CLASS	203		Information	IC - Instrument cluster						V																											
C-CLASS	203		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	203		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	203		Information	CTEL/TEL - Cellular/Mobile telephone																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
C-CLASS	203		Information	AUDIO/COMAND																																	
C-CLASS	203		Information	AGW - Audio gateway																																	
C-CLASS	203		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	203		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	203		Seat/Door	DCM-RR - Door control module rear right		V		V																													
C-CLASS	203		Seat/Door	DCM-RL - Door control module rear left		V																															
C-CLASS	203		Seat/Door	DCM-FR - Door control module front right			V																														
C-CLASS	203		Seat/Door	DCM-FL - Door control module front left	V																																
C-CLASS	203		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	203		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	204		Drive	ME/CDI/CNG - Engine control unit							V																			V			V	V		
C-CLASS	204		Drive	ETC - Electronic transmission control													V												V								
C-CLASS	204		Drive	ESM - Electronic selector module																																	
C-CLASS	204		Drive	SCR - Selective catalytic reduction																																	
C-CLASS	204		Drive	ISM - Intelligent servo module																																	
C-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
C-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	204		Drive	DTR - Distronic																																	
C-CLASS	204		Drive	AMG DRIVE UNIT																																	
C-CLASS	204		Drive	PTCU - Common powertrain controller																																	
C-CLASS	204		Chassis	ABS/ESP - Electronic stability program																				V	V												
C-CLASS	204		Chassis	Suspension																																	
C-CLASS	204		Chassis	ES - Electrical power steering																																	
C-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	204		Body	WSS - Weight sensing system																																	
C-CLASS	204		Body	SCM [MRM] - Steering column module																																	
C-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
C-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
C-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
C-CLASS	204		Body	OCP - Overhead control panel																																	
C-CLASS	204		Body	Multifunction control unit																																	
C-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
C-CLASS	204		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
C-CLASS	204		Body	CGW - Central gateway																																	
C-CLASS	204		Body	AHE - Trailer recognition																																	
C-CLASS	204		Body	AB - Airbag																																	
C-CLASS	204		Information	Head-up display																																	
C-CLASS	204		Information	AVE-H - Rear audio video unit																																	
C-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
C-CLASS	204		Information	ZAN - Audio/COMAND display																																	
C-CLASS	204		Information	TV - TV tuner																																	
C-CLASS	204		Information	Sound generator for exhaust system																																	
C-CLASS	204		Information	SOUND - Sound system																																	
C-CLASS	204		Information	SGR - Radar sensors control unit																																	
C-CLASS	204		Information	360' - Camera																																	
C-CLASS	204		Information	MFK - Multifunction camera																																	
C-CLASS	204		Information	RFK - Backup camera																																	
C-CLASS	204		Information	PTS - Parktronic system																																	
C-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	204		Information	NBR-RF - Right front range radar																																	
C-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	204		Information	NBR-LF - Left front range radar																																	
C-CLASS	204		Information	NAV - Navigation module																																	
C-CLASS	204		Information	MIF/UCI - Media interface																																	
C-CLASS	204		Information	ICI - InCar Internet																																	
C-CLASS	204		Information	IC - Instrument cluster																																	
C-CLASS	204		Information	DVD player																																	
C-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
C-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
C-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
C-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	204		Information	AUDIO/COMAND												V						V															
C-CLASS	204		Information	AMG Performance Media																																	
C-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	204		Seat/Door	HKS - Tailgate control																																	
C-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
C-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	204		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	205		Drive	SCR - Selective catalytic reduction																																	
C-CLASS	205		Drive	SG-EM - Power electronics																																	
C-CLASS	205		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	205		Drive	HFPM - Haptic accelerator pedal module																																	
C-CLASS	205		Drive	DTR - Distronic																																	
C-CLASS	205		Drive	ISM - Intelligent servo module																																	
C-CLASS	205		Drive	ME/CDI/CNG - Engine control unit							V																						V				
C-CLASS	205		Drive	ETC - Electronic transmission control																																	
C-CLASS	205		Drive	PTCU - Common powertrain controller																																	
C-CLASS	205		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	205		Chassis	Suspension																																	
C-CLASS	205		Chassis	ABS/ESP - Electronic stability program										V																							
C-CLASS	205		Chassis	ES - Electrical power steering																																	
C-CLASS	205		Chassis	EFB - Electric parking brake																																	
C-CLASS	205		Information	TPAD - Touchpad																																	
C-CLASS	205		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	205		Information	360' - Camera																																	
C-CLASS	205		Information	Sound generator for exhaust system																																	
C-CLASS	205		Information	SOUND - Sound system																																	
C-CLASS	205		Information	RFK - Backup camera																																	
C-CLASS	205		Information	SGR - Radar sensors control unit																																	
C-CLASS	205		Information	PTS - Parktronic system																																	
C-CLASS	205		Information	NBR-RF - Right front range radar																																	
C-CLASS	205		Information	NBR-LF - Left front range radar																																	
C-CLASS	205		Information	MFK - Multifunction camera																																	
C-CLASS	205		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	205		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	205		Information	Head-up display																																	
C-CLASS	205		Information	AUDIO/COMAND																																	
C-CLASS	205		Information	ZAN - Audio/COMAND display																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
C-CLASS	205		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	205		Information	KAB - Camera cover																																	
C-CLASS	205		Information	IC - Instrument cluster																																	
C-CLASS	205		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	205		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
C-CLASS	205		Body	AHE - Trailer recognition																																	
C-CLASS	205		Body	SCM [MRM] - Steering column module																																	
C-CLASS	205		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	AB - Airbag																																	
C-CLASS	205		Body	Multifunction control unit																																	
C-CLASS	205		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
C-CLASS	205		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	205		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	205		Body	SG-AWF - Collision prevention assist																																	
C-CLASS	205		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	205		Body	BNS/BMS - Battery sensor																																	
C-CLASS	205		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	205		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	205		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	205		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	205		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	205		Seat/Door	HKS - Tailgate control																																	
C-CLASS	205		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	205		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	205		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	205		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	205		Seat/Door	RVC/VDS - Convertible roof control																																	
C-CLASS	205		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	124		Drive	PMS/HFM/LH																																	
E-CLASS	124		Drive	ETC - Electronic transmission control								V																									
E-CLASS	124		Drive	ISC - Idle speed control																																	
E-CLASS	124		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	124		Body	AB - Airbag																																	
E-CLASS	210		Drive	ME/CDI/CNG - Engine control unit									V		V																			V	V		
E-CLASS	210		Drive	ETC - Electronic transmission control								V					V													V							

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
E-CLASS	210		Drive	ESM - Electronic selector module																																	
E-CLASS	210		Chassis	ABS/ESP - Electronic stability program																					V												
E-CLASS	210		Chassis	VP - Vacuum pump brake booster																																	
E-CLASS	210		Chassis	PSE - Pneumatic system equipment																																	
E-CLASS	210		Chassis	BAS - Brake assist																																	
E-CLASS	210		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	210		Body	OCP - Overhead control panel																																	
E-CLASS	210		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	210		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	210		Body	AB - Airbag																																	
E-CLASS	210		Information	TV - TV tuner																																	
E-CLASS	210		Information	PTS - Parktronic system																																	
E-CLASS	210		Information	NAV - Navigation module																																	
E-CLASS	210		Information	IC - Instrument cluster						V										V																	
E-CLASS	210		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	210		Information	AUDIO/COMAND																																	
E-CLASS	210		Information	APS - Auto pilot system																																	
E-CLASS	210		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	210		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	210		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	210		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	210		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	210		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	210		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	210		Air Conditioning	HB - Heater booster																																	
E-CLASS	210		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	211		Drive	ME/CDI/CNG - Engine control unit									V																		V		V	V	V		
E-CLASS	211		Drive	ETC - Electronic transmission control													V													V							
E-CLASS	211		Drive	ESM - Electronic selector module																																	
E-CLASS	211		Drive	Natural gas control unit																																	
E-CLASS	211		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	211		Drive	DTR - Distronic																																	
E-CLASS	211		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	211		Chassis	ABS/ESP - Electronic stability program																			V		V												
E-CLASS	211		Chassis	Suspension																																	
E-CLASS	211		Chassis	SBC - Sensotronic Brake Control																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
E-CLASS	211		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	211		Body	WSS - Weight sensing system					V																												
E-CLASS	211		Body	UCP - Upper control panel																																	
E-CLASS	211		Body	System diagnosis																																	
E-CLASS	211		Body	SCM [MRM] - Steering column module																																	
E-CLASS	211		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	211		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
E-CLASS	211		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V																													
E-CLASS	211		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	OCP - Overhead control panel																																	
E-CLASS	211		Body	Multifunction control unit																																	
E-CLASS	211		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	211		Body	LAE [LAA] - Loading floor automatically extendable																																	
E-CLASS	211		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	211		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	211		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	211		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	211		Body	CGW - Central gateway																																	
E-CLASS	211		Body	BNS/BMS - Battery sensor																																	
E-CLASS	211		Body	AHE - Trailer recognition																																	
E-CLASS	211		Body	AB - Airbag																																	
E-CLASS	211		Information	TV - TV tuner																																	
E-CLASS	211		Information	SOUND - Sound system																																	
E-CLASS	211		Information	PTS - Parktronic system																																	
E-CLASS	211		Information	MIF/UCI - Media interface																																	
E-CLASS	211		Information	IC - Instrument cluster						V																											
E-CLASS	211		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	211		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	211		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	211		Information	AUDIO/COMAND																																	
E-CLASS	211		Information	ASSYST PLUS - PLUS Active Service System																																	
E-CLASS	211		Information	ASSYST Active Service System						V																											
E-CLASS	211		Information	AGW - Audio gateway																																	
E-CLASS	211		Seat/Door	REDC/RWT - Rear end door control module																																	
E-CLASS	211		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
E-CLASS	211		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	211		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	211		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	211		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DCM-RR - Door control module rear right				V																													
E-CLASS	211		Seat/Door	DCM-RL - Door control module rear left		V																															
E-CLASS	211		Seat/Door	DCM-FR - Door control module front right			V																														
E-CLASS	211		Seat/Door	DCM-FL - Door control module front left	V																																
E-CLASS	211		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	211		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	207		Drive	SG-EM - Power electronics																																	
E-CLASS	207		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	207		Drive	ME/CDI/CNG - Engine control unit							V																			V			V	V		
E-CLASS	207		Drive	ETC - Electronic transmission control													V												V								
E-CLASS	207		Drive	ESM - Electronic selector module																																	
E-CLASS	207		Drive	ISM - Intelligent servo module																																	
E-CLASS	207		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	207		Drive	DTR - Distronic																																	
E-CLASS	207		Drive	DSI - Direct select interface																																	
E-CLASS	207		Drive	AMG DRIVE UNIT																																	
E-CLASS	207		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	207		Chassis	Suspension																																	
E-CLASS	207		Chassis	ES - Electrical power steering																																	
E-CLASS	207		Chassis	FWGW - Chassis gateway																																	
E-CLASS	207		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	207		Body	BNS/BMS - Battery sensor																																	
E-CLASS	207		Body	WSS - Weight sensing system																																	
E-CLASS	207		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	207		Body	SCM [MRM] - Steering column module																																	
E-CLASS	207		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	207		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																V																	
E-CLASS	207		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
E-CLASS	207		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
E-CLASS	207		Body	Multifunction control unit																																	
E-CLASS	207		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
E-CLASS	207		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
E-CLASS	207		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	207		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	207		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	207		Body	CGW - Central gateway																																	
E-CLASS	207		Body	AHE - Trailer recognition																																	
E-CLASS	207		Body	AB - Airbag																																	
E-CLASS	207		Information	NBR-RF - Right front range radar																																	
E-CLASS	207		Information	NBR-LF - Left front range radar																																	
E-CLASS	207		Information	AVE-H - Rear audio video unit																																	
E-CLASS	207		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	207		Information	ZAN - Audio/COMAND display																																	
E-CLASS	207		Information	TV - TV tuner																																	
E-CLASS	207		Information	SOUND - Sound system																																	
E-CLASS	207		Information	SGR - Radar sensors control unit																																	
E-CLASS	207		Information	360' - Camera																																	
E-CLASS	207		Information	MFK - Multifunction camera																																	
E-CLASS	207		Information	RFK - Backup camera																																	
E-CLASS	207		Information	PTS - Parktronic system																																	
E-CLASS	207		Information	NSA - Night View Assist																																	
E-CLASS	207		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	207		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	207		Information	NAV - Navigation module																																	
E-CLASS	207		Information	MIF/UCI - Media interface																																	
E-CLASS	207		Information	ICI - InCar Internet																																	
E-CLASS	207		Information	IC - Instrument cluster																																	
E-CLASS	207		Information	DVD player																																	
E-CLASS	207		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	207		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	207		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	207		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	207		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	207		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	207		Information	AUDIO/COMAND												V						V															
E-CLASS	207		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	207		Seat/Door	PSD/MSC - Sliding roof control																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
E-CLASS	207		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	207		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	207		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	207		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	207		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	207		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	207		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	212		Drive	SG-EM - Power electronics																																	
E-CLASS	212		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	212		Drive	ME/CDI/CNG - Engine control unit							V																				V			V	V		
E-CLASS	212		Drive	ETC - Electronic transmission control													V													V							
E-CLASS	212		Drive	ESM - Electronic selector module																																	
E-CLASS	212		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	212		Drive	ISM - Intelligent servo module																																	
E-CLASS	212		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	212		Drive	DTR - Distronic																																	
E-CLASS	212		Drive	DSI - Direct select interface																																	
E-CLASS	212		Drive	AMG DRIVE UNIT																																	
E-CLASS	212		Chassis	ABS/ESP - Electronic stability program																				V	V												
E-CLASS	212		Chassis	Suspension																																	
E-CLASS	212		Chassis	ES - Electrical power steering																																	
E-CLASS	212		Chassis	FWGW - Chassis gateway																																	
E-CLASS	212		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	212		Body	BNS/BMS - Battery sensor																																	
E-CLASS	212		Body	WSS - Weight sensing system																																	
E-CLASS	212		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	212		Body	SCM [MRM] - Steering column module																																	
E-CLASS	212		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	212		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																V																	
E-CLASS	212		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
E-CLASS	212		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
E-CLASS	212		Body	OCP - Overhead control panel																																	
E-CLASS	212		Body	Multifunction control unit																																	
E-CLASS	212		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
E-CLASS	212		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	212		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
E-CLASS	212		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	212		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	212		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	212		Body	CGW - Central gateway																																	
E-CLASS	212		Body	AHE - Trailer recognition																																	
E-CLASS	212		Body	AB - Airbag																																	
E-CLASS	212		Information	Head-up display																																	
E-CLASS	212		Information	AVE-H - Rear audio video unit																																	
E-CLASS	212		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	212		Information	ZAN - Audio/COMAND display																																	
E-CLASS	212		Information	TV - TV tuner																																	
E-CLASS	212		Information	SOUND - Sound system																																	
E-CLASS	212		Information	SGR - Radar sensors control unit																																	
E-CLASS	212		Information	360' - Camera																																	
E-CLASS	212		Information	MFK - Multifunction camera																																	
E-CLASS	212		Information	RFK - Backup camera																																	
E-CLASS	212		Information	PTS - Parktronic system																																	
E-CLASS	212		Information	NSA - Night View Assist																																	
E-CLASS	212		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	212		Information	NBR-RF - Right front range radar																																	
E-CLASS	212		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	212		Information	NBR-LF - Left front range radar																																	
E-CLASS	212		Information	NAV - Navigation module																																	
E-CLASS	212		Information	MIF/UCI - Media interface																																	
E-CLASS	212		Information	ICI - InCar Internet																																	
E-CLASS	212		Information	IC - Instrument cluster																																	
E-CLASS	212		Information	DVD player																																	
E-CLASS	212		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	212		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	212		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	212		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	212		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	212		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	212		Information	AUDIO/COMAND												V						V															
E-CLASS	212		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	212		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
E-CLASS	212		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	212		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	212		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	212		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	212		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	212		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	212		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	212		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	212		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	212		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	213		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	213		Drive	DTR - Distronic																																	
E-CLASS	213		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	213		Drive	HFPM - Haptic accelerator pedal module																																	
E-CLASS	213		Drive	AMG DRIVE UNIT																																	
E-CLASS	213		Drive	PTCU - Common powertrain controller																																	
E-CLASS	213		Drive	ME/CDI/CNG - Engine control unit							V																						V				
E-CLASS	213		Drive	ETC - Electronic transmission control																																	
E-CLASS	213		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	213		Chassis	AIRMATIC PLUS																																	
E-CLASS	213		Chassis	ES - Electrical power steering																																	
E-CLASS	213		Chassis	Suspension																																	
E-CLASS	213		Chassis	ABS/ESP - Electronic stability program										V																							
E-CLASS	213		Body	MTAS - Mobile phone cradle																																	
E-CLASS	213		Body	AHE - Trailer recognition																																	
E-CLASS	213		Body	SCM [MRM] - Steering column module																																	
E-CLASS	213		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
E-CLASS	213		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
E-CLASS	213		Body	AB - Airbag																																	
E-CLASS	213		Body	OCP - Overhead control panel																																	
E-CLASS	213		Body	Multifunction control unit																																	
E-CLASS	213		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
E-CLASS	213		Body	SG-DDW - DC/DC converter control unit																																	
E-CLASS	213		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	213		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	213		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	213		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	213		Body	BNS/BMS - Battery sensor																																	
E-CLASS	213		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	213		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	213		Body	AML - Ambiance light																																	
E-CLASS	213		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	213		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	213		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
E-CLASS	213		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
E-CLASS	213		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	213		Seat/Door	HKS - Tailgate control																																	
E-CLASS	213		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	213		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	213		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	213		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	213		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	213		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	213		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	213		Information	TPAD - Touchpad																																	
E-CLASS	213		Information	Sound generator for exhaust system																																	
E-CLASS	213		Information	SOUND - Sound system																																	
E-CLASS	213		Information	RFK - Backup camera																																	
E-CLASS	213		Information	PTS - Parktronic system																																	
E-CLASS	213		Information	MFK - Multifunction camera																																	
E-CLASS	213		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	213		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	213		Information	SGR - Radar sensors control unit																																	
E-CLASS	213		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
E-CLASS	213		Information	Head-up display																																	
E-CLASS	213		Information	AUDIO/COMAND																																	
E-CLASS	213		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	213		Information	ZAN - Audio/COMAND display																																	
E-CLASS	213		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	213		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	140		Drive	ASF																																	
S-CLASS	140		Drive	ERE																																	
S-CLASS	140		Drive	ME1LI																																	
S-CLASS	140		Drive	ME1RE																																	
S-CLASS	140		Drive	HFM/ME2/LH																																	
S-CLASS	140		Drive	ETC - Electronic transmission control								V																									
S-CLASS	140		Drive	ISC - Idle speed control																																	
S-CLASS	140		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	140		Chassis	BAS - Brake assist																																	
S-CLASS	140		Body	PSE - Pneumatic system equipment																																	
S-CLASS	140		Body	AB - Airbag																																	
S-CLASS	140		Information	PTS - Parktronic system																																	
S-CLASS	140		Information	IC - Instrument cluster																																	
S-CLASS	140		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	220		Drive	ME/CDI/CNG - Engine control unit									V		V															V		V	V	V		
S-CLASS	220		Drive	ETC - Electronic transmission control								V					V												V								
S-CLASS	220		Drive	ESM - Electronic selector module																																	
S-CLASS	220		Drive	DTR - Distronic																																	
S-CLASS	220		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	220		Chassis	Suspension																																	
S-CLASS	220		Chassis	PSE - Pneumatic system equipment																																	
S-CLASS	220		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	220		Body	UCP - Upper control panel																																	
S-CLASS	220		Body	System diagnosis																																	
S-CLASS	220		Body	SCM [MRM] - Steering column module																																	
S-CLASS	220		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	220		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
S-CLASS	220		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	220		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	220		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
S-CLASS	220		Body	OCP - Overhead control panel																																	
S-CLASS	220		Body	Multifunction control unit																																	
S-CLASS	220		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	220		Body	HSW/LRH - Steering wheel heater																																	
S-CLASS	220		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	220		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	220		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	220		Body	CGW - Central gateway																																	
S-CLASS	220		Body	AHE - Trailer recognition																																	
S-CLASS	220		Body	AB - Airbag																																	
S-CLASS	220		Information	TV - TV tuner																																	
S-CLASS	220		Information	PTS - Parktronic system																																	
S-CLASS	220		Information	NAV - Navigation module																																	
S-CLASS	220		Information	IC - Instrument cluster						V										V																	
S-CLASS	220		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	220		Information	AUDIO/COMAND																																	
S-CLASS	220		Information	AGW - Audio gateway																																	
S-CLASS	220		Seat/Door	OSB-R - Multicontour backrest rear																																	
S-CLASS	220		Seat/Door	OSB-FL - Multicontour backrest front left																																	
S-CLASS	220		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	220		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	220		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	220		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	220		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	220		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	220		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	220		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	220		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	220		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	220		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	221		Drive	ME/CDI/CNG - Engine control unit							V																				V		V	V			
S-CLASS	221		Drive	ETC - Electronic transmission control													V													V							
S-CLASS	221		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	221		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
S-CLASS	221		Drive	HSG - Hybrid control unit										V																							
S-CLASS	221		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	221		Drive	DTR - Distronic																																	
S-CLASS	221		Chassis	ABS/ESP - Electronic stability program																				V	V												
S-CLASS	221		Chassis	Suspension																																	
S-CLASS	221		Chassis	ES - Electrical power steering																																	
S-CLASS	221		Chassis	EFB - Electric parking brake																																	
S-CLASS	221		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	221		Body	WSS - Weight sensing system																																	
S-CLASS	221		Body	UCP - Upper control panel																																	
S-CLASS	221		Body	System diagnosis																																	
S-CLASS	221		Body	SG-DDW - DC/DC converter control unit																																	
S-CLASS	221		Body	SCM [MRM] - Steering column module																																	
S-CLASS	221		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	221		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	221		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
S-CLASS	221		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
S-CLASS	221		Body	OCP - Overhead control panel																																	
S-CLASS	221		Body	Multifunction control unit																																	
S-CLASS	221		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
S-CLASS	221		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	221		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	221		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	221		Body	CGW - Central gateway																																	
S-CLASS	221		Body	BNS/BMS - Battery sensor																																	
S-CLASS	221		Body	AHE - Trailer recognition																																	
S-CLASS	221		Body	AB - Airbag																																	
S-CLASS	221		Information	ZAN - Audio/COMAND display																																	
S-CLASS	221		Information	VCS - Voice control																																	
S-CLASS	221		Information	TV - TV tuner																																	
S-CLASS	221		Information	Tuner - Standard tuner																																	
S-CLASS	221		Information	SOUND - Sound system																																	
S-CLASS	221		Information	SGR - Radar sensors control unit																																	
S-CLASS	221		Information	MFK - Multifunction camera																																	
S-CLASS	221		Information	RFK - Backup camera																																	
S-CLASS	221		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
S-CLASS	221		Information	NSA - Night View Assist																																	
S-CLASS	221		Information	NBR-LF - Left front range radar																																	
S-CLASS	221		Information	NAV - Navigation module																																	
S-CLASS	221		Information	MIF/UCI - Media interface																																	
S-CLASS	221		Information	ICI - InCar Internet																																	
S-CLASS	221		Information	IC - Instrument cluster																																	
S-CLASS	221		Information	DVD player																																	
S-CLASS	221		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	221		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	221		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	221		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	221		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	221		Information	AVE-H - Rear audio video unit																																	
S-CLASS	221		Information	AUDIO/COMAND												V						V															
S-CLASS	221		Information	ASSYST PLUS - PLUS Active Service System																																	
S-CLASS	221		Information	ASSYST Active Service System																																	
S-CLASS	221		Seat/Door	TSG-MR - Right center door control unit																																	
S-CLASS	221		Seat/Door	TSG-ML - Left center door control unit																																	
S-CLASS	221		Seat/Door	TLC/GTO - Garage door opener																																	
S-CLASS	221		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	221		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
S-CLASS	221		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
S-CLASS	221		Seat/Door	HKS - Tailgate control																																	
S-CLASS	221		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	221		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	221		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	221		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	221		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	221		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	221		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	221		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	221		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	221		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	221		Air Conditioning	HBF - Rear control panel																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
S-CLASS	221		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	217		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	217		Drive	SG-EM - Power electronics																																	
S-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	217		Drive	DTR - Distronic																																	
S-CLASS	217		Drive	ISM - Intelligent servo module																																	
S-CLASS	217		Drive	PTCU - Common powertrain controller																																	
S-CLASS	217		Drive	ME/CDI/CNG - Engine control unit							V																						V				
S-CLASS	217		Drive	ETC - Electronic transmission control																																	
S-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	217		Chassis	ABS/ESP - Electronic stability program										V																							
S-CLASS	217		Chassis	ES - Electrical power steering																																	
S-CLASS	217		Chassis	Suspension																																	
S-CLASS	217		Chassis	EFB - Electric parking brake																																	
S-CLASS	217		Information	TPAD - Touchpad																																	
S-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	217		Information	360' - Camera																																	
S-CLASS	217		Information	SOUND - Sound system																																	
S-CLASS	217		Information	RFK - Backup camera																																	
S-CLASS	217		Information	SGR - Radar sensors control unit																																	
S-CLASS	217		Information	PTS - Parktronic system																																	
S-CLASS	217		Information	NSA - Night View Assist																																	
S-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	217		Information	NBR-RF - Right front range radar																																	
S-CLASS	217		Information	NBR-LF - Left front range radar																																	
S-CLASS	217		Information	MFK - Multifunction camera																																	
S-CLASS	217		Information	Head-up display																																	
S-CLASS	217		Information	AUDIO/COMAND																																	
S-CLASS	217		Information	ZAN - Audio/COMAND display																																	
S-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	217		Information	KAB - Camera cover																																	
S-CLASS	217		Information	IC - Instrument cluster																																	
S-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	217		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
S-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	AB - Airbag																																	
S-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
S-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	217		Body	BNS/BMS - Battery sensor																																	
S-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	217		Seat/Door	HKS - Tailgate control																																	
S-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
S-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	222		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	222		Drive	SG-EM - Power electronics																																	
S-CLASS	222		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	222		Drive	DTR - Distronic																																	
S-CLASS	222		Drive	ISM - Intelligent servo module																																	
S-CLASS	222		Drive	PTCU - Common powertrain controller																																	
S-CLASS	222		Drive	ME/CDI/CNG - Engine control unit							V																						V				
S-CLASS	222		Drive	ETC - Electronic transmission control																																	
S-CLASS	222		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	222		Chassis	ES - Electrical power steering																																	
S-CLASS	222		Chassis	ABS/ESP - Electronic stability program										V																							
S-CLASS	222		Chassis	Suspension																																	
S-CLASS	222		Chassis	EFB - Electric parking brake																																	
S-CLASS	222		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
S-CLASS	222		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	222		Information	360' - Camera																																	
S-CLASS	222		Information	Sound generator for exhaust system																																	
S-CLASS	222		Information	SOUND - Sound system																																	
S-CLASS	222		Information	RFK - Backup camera																																	
S-CLASS	222		Information	SGR - Radar sensors control unit																																	
S-CLASS	222		Information	PTS - Parktronic system																																	
S-CLASS	222		Information	NSA - Night View Assist																																	
S-CLASS	222		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	222		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	222		Information	NBR-RF - Right front range radar																																	
S-CLASS	222		Information	NBR-LF - Left front range radar																																	
S-CLASS	222		Information	MFK - Multifunction camera																																	
S-CLASS	222		Information	Head-up display																																	
S-CLASS	222		Information	AUDIO/COMAND																																	
S-CLASS	222		Information	AVE-H - Rear audio video unit																																	
S-CLASS	222		Information	ZAN - Audio/COMAND display																																	
S-CLASS	222		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	222		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	222		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	222		Information	KAB - Camera cover																																	
S-CLASS	222		Information	IC - Instrument cluster																																	
S-CLASS	222		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	222		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	222		Body	AHE - Trailer recognition																																	
S-CLASS	222		Body	SCM [MRM] - Steering column module																																	
S-CLASS	222		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	AB - Airbag																																	
S-CLASS	222		Body	Multifunction control unit																																	
S-CLASS	222		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
S-CLASS	222		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	222		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	222		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
S-CLASS	222		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	222		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
S-CLASS	222		Body	BNS/BMS - Battery sensor																																	
S-CLASS	222		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	222		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	222		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	222		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	222		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
S-CLASS	222		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
S-CLASS	222		Seat/Door	HKS - Tailgate control																																	
S-CLASS	222		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	222		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	222		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	222		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	222		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	222		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	222		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	222		Air Conditioning	AAC - Automatic air conditioning																																	
G-CLASS	461 - 38P Connector		Drive	EVE																																	
G-CLASS	461 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 38P Connector		Information	IC - Instrument cluster																																	
G-CLASS	461 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	461 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit							V		V																				V	V	V	
G-CLASS	461 - 16P Connector		Drive	ETC - Electronic transmission control													V													V							
G-CLASS	461 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	461 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	461 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																			V		V												
G-CLASS	461 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	461 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	461 - 16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
G-CLASS	461 - 16P Connector		Body	CGW - Central gateway																																	
G-CLASS	461 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 16P Connector		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
G-CLASS	461 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	461 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	461 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 38P Connector		Drive	ME/CDI/CNG - Engine control unit											V																						
G-CLASS	463 - 38P Connector		Drive	ETC - Electronic transmission control								V																									
G-CLASS	463 - 38P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 38P Connector		Drive	CC - Cruise control																																	
G-CLASS	463 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	463 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 38P Connector		Information	IC - Instrument cluster						V										V																	
G-CLASS	463 - 38P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 38P Connector		Information	APS - Auto pilot system																																	
G-CLASS	463 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit							V		V																		V		V	V	V		
G-CLASS	463 - 16P Connector		Drive	ETC - Electronic transmission control													V													V							
G-CLASS	463 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	463 - 16P Connector		Drive	SCR - Selective catalytic reduction																																	
G-CLASS	463 - 16P Connector		Drive	ISM - Intelligent servo module																																	
G-CLASS	463 - 16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
G-CLASS	463 - 16P Connector		Drive	DTR - Distronic																																	
G-CLASS	463 - 16P Connector		Drive	DSI - Direct select interface																																	
G-CLASS	463 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																			V		V												
G-CLASS	463 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	463 - 16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
G-CLASS	463 - 16P Connector		Body	UCP - Upper control panel																																	
G-CLASS	463 - 16P Connector		Body	SCM [MRM] - Steering column module																																	
G-CLASS	463 - 16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
G-CLASS	463 - 16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V													V																
G-CLASS	463 - 16P Connector		Body	OCP - Overhead control panel																																	
G-CLASS	463 - 16P Connector		Body	Multifunction control unit																																	
G-CLASS	463 - 16P Connector		Body	HSW/LRH - Steering wheel heater																																	
G-CLASS	463 - 16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
G-CLASS	463 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	463 - 16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
G-CLASS	463 - 16P Connector		Body	AHE - Trailer recognition																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
G-CLASS	463 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 16P Connector		Information	ZAN - Audio/COMAND display																																	
G-CLASS	463 - 16P Connector		Information	TV - TV tuner																																	
G-CLASS	463 - 16P Connector		Information	SOUND - Sound system																																	
G-CLASS	463 - 16P Connector		Information	PTS - Parktronic system																																	
G-CLASS	463 - 16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NAV - Navigation module																																	
G-CLASS	463 - 16P Connector		Information	MIF/UCI - Media interface																																	
G-CLASS	463 - 16P Connector		Information	IC - Instrument cluster						V																											
G-CLASS	463 - 16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
G-CLASS	463 - 16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
G-CLASS	463 - 16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
G-CLASS	463 - 16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
G-CLASS	463 - 16P Connector		Information	AUDIO/COMAND												V						V															
G-CLASS	463 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	463 - 16P Connector		Seat/Door	HS - Seat heater																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RR - Door control module rear right		V		V																													
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RL - Door control module rear left		V																															
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FR - Door control module front right			V																														
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FL - Door control module front left	V																																
G-CLASS	463 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Air Conditioning	AAC - Automatic air conditioning																																	
GLA-CLASS	156		Drive	VG - Transfer case																																	
GLA-CLASS	156		Drive	ME/CDI/CNG - Engine control unit							V																						V				
GLA-CLASS	156		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLA-CLASS	156		Drive	ETC - Electronic transmission control																																	
GLA-CLASS	156		Drive	DTR - Distronic																																	
GLA-CLASS	156		Drive	DSI - Direct select interface																																	
GLA-CLASS	156		Drive	PTCU - Common powertrain controller																																	
GLA-CLASS	156		Chassis	ABS/ESP - Electronic stability program																																	
GLA-CLASS	156		Chassis	ES - Electrical power steering																																	
GLA-CLASS	156		Chassis	EFB - Electric parking brake										V																							
GLA-CLASS	156		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
GLA-CLASS	156		Body	SG-AWF - Collision prevention assist																																	
GLA-CLASS	156		Body	SCM [MRM] - Steering column module																																	
GLA-CLASS	156		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
GLA-CLASS	156		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
GLA-CLASS	156		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
GLA-CLASS	156		Body	Multifunction control unit																																	
GLA-CLASS	156		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
GLA-CLASS	156		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLA-CLASS	156		Body	EZS/EIS - Electronic ignition lock																																	
GLA-CLASS	156		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLA-CLASS	156		Body	AHE - Trailer recognition																																	
GLA-CLASS	156		Body	AB - Airbag																																	
GLA-CLASS	156		Information	Head-up display																																	
GLA-CLASS	156		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLA-CLASS	156		Information	KAB - Camera cover																																	
GLA-CLASS	156		Information	ZAN - Audio/COMAND display																																	
GLA-CLASS	156		Information	TV - TV tuner																																	
GLA-CLASS	156		Information	SOUND - Sound system																																	
GLA-CLASS	156		Information	RFK - Backup camera																																	
GLA-CLASS	156		Information	MFK - Multifunction camera																																	
GLA-CLASS	156		Information	PTS - Parktronic system																																	
GLA-CLASS	156		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLA-CLASS	156		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLA-CLASS	156		Information	NAV - Navigation module																																	
GLA-CLASS	156		Information	MIF/UCI - Media interface																																	
GLA-CLASS	156		Information	IC - Instrument cluster																																	
GLA-CLASS	156		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLA-CLASS	156		Information	DAB/SDAR - Digital/Satellite radio																																	
GLA-CLASS	156		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLA-CLASS	156		Information	AUDIO/COMAND												V						V															
GLA-CLASS	156		Seat/Door	HKS - Tailgate control																																	
GLA-CLASS	156		Seat/Door	PSD/MSC - Sliding roof control																																	
GLA-CLASS	156		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLA-CLASS	156		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLA-CLASS	156		Seat/Door	DCM-FR - Door control module front right																																	
GLA-CLASS	156		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
GLA-CLASS	156		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLA-CLASS	156		Air Conditioning	AAC - Automatic air conditioning																																	
GLK-CLASS	204		Drive	ME/CDI/CNG - Engine control unit							V																				V		V	V		
GLK-CLASS	204		Drive	ETC - Electronic transmission control													V													V							
GLK-CLASS	204		Drive	ESM - Electronic selector module																																	
GLK-CLASS	204		Drive	SCR - Selective catalytic reduction																																	
GLK-CLASS	204		Drive	PTCU - Common powertrain controller																																	
GLK-CLASS	204		Drive	ISM - Intelligent servo module																																	
GLK-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
GLK-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLK-CLASS	204		Drive	DTR - Distronic																																	
GLK-CLASS	204		Drive	AMG DRIVE UNIT																																	
GLK-CLASS	204		Chassis	ABS/ESP - Electronic stability program																				V	V												
GLK-CLASS	204		Chassis	Suspension																																	
GLK-CLASS	204		Chassis	ES - Electrical power steering																																	
GLK-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
GLK-CLASS	204		Body	WSS - Weight sensing system																																	
GLK-CLASS	204		Body	SCM [MRM] - Steering column module																																	
GLK-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLK-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
GLK-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
GLK-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
GLK-CLASS	204		Body	OCP - Overhead control panel																																	
GLK-CLASS	204		Body	Multifunction control unit																																	
GLK-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
GLK-CLASS	204		Body	Headlamp-R - Headlamp control unit																																	
GLK-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLK-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	
GLK-CLASS	204		Body	CGW - Central gateway																																	
GLK-CLASS	204		Body	AHE - Trailer recognition																																	
GLK-CLASS	204		Body	AB - Airbag																																	
GLK-CLASS	204		Information	Head-up display																																	
GLK-CLASS	204		Information	AVE-H - Rear audio video unit																																	
GLK-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLK-CLASS	204		Information	ZAN - Audio/COMAND display																																	
GLK-CLASS	204		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
GLK-CLASS	204		Information	Sound generator for exhaust system																																	
GLK-CLASS	204		Information	SOUND - Sound system																																	
GLK-CLASS	204		Information	SGR - Radar sensors control unit																																	
GLK-CLASS	204		Information	360' - Camera																																	
GLK-CLASS	204		Information	MFK - Multifunction camera																																	
GLK-CLASS	204		Information	RFK - Backup camera																																	
GLK-CLASS	204		Information	PTS - Parktronic system																																	
GLK-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLK-CLASS	204		Information	NBR-RF - Right front range radar																																	
GLK-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLK-CLASS	204		Information	NBR-LF - Left front range radar																																	
GLK-CLASS	204		Information	NAV - Navigation module																																	
GLK-CLASS	204		Information	MIF/UCI - Media interface																																	
GLK-CLASS	204		Information	ICI - InCar Internet																																	
GLK-CLASS	204		Information	IC - Instrument cluster																																	
GLK-CLASS	204		Information	DVD player																																	
GLK-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLK-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
GLK-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
GLK-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
GLK-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GLK-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLK-CLASS	204		Information	AUDIO/COMAND												V						V															
GLK-CLASS	204		Information	AMG Performance Media																																	
GLK-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
GLK-CLASS	204		Seat/Door	HKS - Tailgate control																																	
GLK-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLK-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLK-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
GLK-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
GLK-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
GLK-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
GLK-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLK-CLASS	204		Air Conditioning	AAC - Automatic air conditioning																																	
GLC-CLASS	253		Drive	SCR - Selective catalytic reduction																																	
GLC-CLASS	253		Drive	SG-EM - Power electronics																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
GLC-CLASS	253		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLC-CLASS	253		Drive	DTR - Distronic																																	
GLC-CLASS	253		Drive	ISM - Intelligent servo module																																	
GLC-CLASS	253		Drive	PTCU - Common powertrain controller																																	
GLC-CLASS	253		Drive	ME/CDI/CNG - Engine control unit							V																						V				
GLC-CLASS	253		Drive	ETC - Electronic transmission control																																	
GLC-CLASS	253		Chassis	TPM - Tire pressure monitor																																	
GLC-CLASS	253		Chassis	AIRMATIC PLUS																																	
GLC-CLASS	253		Chassis	ES - Electrical power steering																																	
GLC-CLASS	253		Chassis	Suspension																																	
GLC-CLASS	253		Chassis	ABS/ESP - Electronic stability program										V																							
GLC-CLASS	253		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLC-CLASS	253		Body	AHE - Trailer recognition																																	
GLC-CLASS	253		Body	SCM [MRM] - Steering column module																																	
GLC-CLASS	253		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	AB - Airbag																																	
GLC-CLASS	253		Body	Multifunction control unit																																	
GLC-CLASS	253		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
GLC-CLASS	253		Body	Headlamp-R - Headlamp control unit																																	
GLC-CLASS	253		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLC-CLASS	253		Body	SG-AWF - Collision prevention assist																																	
GLC-CLASS	253		Body	EZS/EIS - Electronic ignition lock																																	
GLC-CLASS	253		Body	BNS/BMS - Battery sensor																																	
GLC-CLASS	253		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLC-CLASS	253		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLC-CLASS	253		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLC-CLASS	253		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLC-CLASS	253		Seat/Door	PSD/MSC - Sliding roof control																																	
GLC-CLASS	253		Seat/Door	HKS - Tailgate control																																	
GLC-CLASS	253		Seat/Door	DCM-RR - Door control module rear right																																	
GLC-CLASS	253		Seat/Door	DCM-RL - Door control module rear left																																	
GLC-CLASS	253		Seat/Door	DCM-FR - Door control module front right																																	
GLC-CLASS	253		Seat/Door	DCM-FL - Door control module front left																																	
GLC-CLASS	253		Information	TPAD - Touchpad																																	
GLC-CLASS	253		Information	DAB/SDAR - Digital/Satellite radio																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
GLC-CLASS	253		Information	360' - Camera																																	
GLC-CLASS	253		Information	Sound generator for exhaust system																																	
GLC-CLASS	253		Information	SOUND - Sound system																																	
GLC-CLASS	253		Information	RFK - Backup camera																																	
GLC-CLASS	253		Information	SGR - Radar sensors control unit																																	
GLC-CLASS	253		Information	PTS - Parktronic system																																	
GLC-CLASS	253		Information	NBR-RF - Right front range radar																																	
GLC-CLASS	253		Information	NBR-LF - Left front range radar																																	
GLC-CLASS	253		Information	MFK - Multifunction camera																																	
GLC-CLASS	253		Information	IC - Instrument cluster																																	
GLC-CLASS	253		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLC-CLASS	253		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLC-CLASS	253		Information	Head-up display																																	
GLC-CLASS	253		Information	AUDIO/COMAND																																	
GLC-CLASS	253		Information	SG-MSND - Engine sound																																	
GLC-CLASS	253		Information	ZAN - Audio/COMAND display																																	
GLC-CLASS	253		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLC-CLASS	253		Information	KAB - Camera cover																																	
GLC-CLASS	253		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLC-CLASS	253		Information	AMG Performance Media																																	
GLC-CLASS	253		Air Conditioning	AAC - Automatic air conditioning																																	
GLE-CLASS	292		Drive	SCR - Selective catalytic reduction																																	
GLE-CLASS	292		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLE-CLASS	292		Drive	ISM - Intelligent servo module																																	
GLE-CLASS	292		Drive	DTR - Distronic																																	
GLE-CLASS	292		Drive	ME/CDI/CNG - Engine control unit							V																						V				
GLE-CLASS	292		Drive	ETC - Electronic transmission control																																	
GLE-CLASS	292		Chassis	TPM - Tire pressure monitor																																	
GLE-CLASS	292		Chassis	FWGW - Chassis gateway																																	
GLE-CLASS	292		Chassis	ABS/ESP - Electronic stability program																				V	V												
GLE-CLASS	292		Chassis	ES - Electrical power steering																																	
GLE-CLASS	292		Chassis	EFB - Electric parking brake										V																							
GLE-CLASS	292		Chassis	Suspension																																	
GLE-CLASS	292		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLE-CLASS	292		Body	AHE - Trailer recognition																																	
GLE-CLASS	292		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
GLE-CLASS	292		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
GLE-CLASS	292		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
GLE-CLASS	292		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLE-CLASS	292		Body	AB - Airbag																																	
GLE-CLASS	292		Body	Multifunction control unit																																	
GLE-CLASS	292		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
GLE-CLASS	292		Body	Headlamp-R - Headlamp control unit																																	
GLE-CLASS	292		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLE-CLASS	292		Body	SG-AWF - Collision prevention assist																																	
GLE-CLASS	292		Body	EZS/EIS - Electronic ignition lock																																	
GLE-CLASS	292		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
GLE-CLASS	292		Information	TPAD - Touchpad																																	
GLE-CLASS	292		Information	DAB/SDAR - Digital/Satellite radio																																	
GLE-CLASS	292		Information	360' - Camera																																	
GLE-CLASS	292		Information	SOUND - Sound system																																	
GLE-CLASS	292		Information	RFK - Backup camera																																	
GLE-CLASS	292		Information	SGR - Radar sensors control unit																																	
GLE-CLASS	292		Information	PTS - Parktronic system																																	
GLE-CLASS	292		Information	MFK - Multifunction camera																																	
GLE-CLASS	292		Information	NBR-RF - Right front range radar																																	
GLE-CLASS	292		Information	NBR-LF - Left front range radar																																	
GLE-CLASS	292		Information	IC - Instrument cluster																																	
GLE-CLASS	292		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLE-CLASS	292		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLE-CLASS	292		Information	Head-up display																																	
GLE-CLASS	292		Information	AUDIO/COMAND																																	
GLE-CLASS	292		Information	AVE-H - Rear audio video unit																																	
GLE-CLASS	292		Information	DVD player																																	
GLE-CLASS	292		Information	SG-MSND - Engine sound																																	
GLE-CLASS	292		Information	ZAN - Audio/COMAND display																																	
GLE-CLASS	292		Information	D-FOR - Display in right rear passenger																																	
GLE-CLASS	292		Information	D-FOL - Display in left rear passenger																																	
GLE-CLASS	292		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLE-CLASS	292		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLE-CLASS	292		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLE-CLASS	292		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
GLE-CLASS	292		Seat/Door	PSD/MSC - Sliding roof control																																	
GLE-CLASS	292		Seat/Door	HKS - Tailgate control																																	
GLE-CLASS	292		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DCM-RR - Door control module rear right																																	
GLE-CLASS	292		Seat/Door	DCM-RL - Door control module rear left																																	
GLE-CLASS	292		Seat/Door	DCM-FR - Door control module front right																																	
GLE-CLASS	292		Seat/Door	DCM-FL - Door control module front left																																	
GLE-CLASS	292		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLE-CLASS	292		Air Conditioning	HBF - Rear control panel																																	
GLE-CLASS	292		Air Conditioning	AAC - Automatic air conditioning																																	
GL-CLASS	164		Drive	ME/CDI/CNG - Engine control unit							V		V																	V			V	V	V	
GL-CLASS	164		Drive	ETC - Electronic transmission control																																	
GL-CLASS	164		Drive	VG - Transfer case																																	
GL-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
GL-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
GL-CLASS	164		Drive	SCR - Selective catalytic reduction																																	
GL-CLASS	164		Drive	ISM - Intelligent servo module																																	
GL-CLASS	164		Drive	HSG - Hybrid control unit										V																							
GL-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
GL-CLASS	164		Drive	DTR - Distronic																																	
GL-CLASS	164		Chassis	ABS/ESP - Electronic stability program																			V		V												
GL-CLASS	164		Chassis	Suspension																																	
GL-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
GL-CLASS	164		Chassis	ES - Electrical power steering																																	
GL-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	164		Body	WSS - Weight sensing system					V																												
GL-CLASS	164		Body	UCP - Upper control panel																																	
GL-CLASS	164		Body	System diagnosis																																	
GL-CLASS	164		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V																													
GL-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
GL-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
GL-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	164		Body	CGW - Central gateway																																	
GL-CLASS	164		Body	AB - Airbag																																	
GL-CLASS	164		Information	TV - TV tuner																																	
GL-CLASS	164		Information	SOUND - Sound system																																	
GL-CLASS	164		Information	RFK - Backup camera																																	
GL-CLASS	164		Information	PTS - Parktronic system																																	
GL-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	164		Information	NAV - Navigation module																																	
GL-CLASS	164		Information	MIF/UCI - Media interface																																	
GL-CLASS	164		Information	IC - Instrument cluster						V																											
GL-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GL-CLASS	164		Information	CM - Compass module																																	
GL-CLASS	164		Information	AVE-H - Rear audio video unit																																	
GL-CLASS	164		Information	AUDIO/COMAND																																	
GL-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
GL-CLASS	164		Information	ASSYST Active Service System						V																											
GL-CLASS	164		Information	AGW - Audio gateway																																	
GL-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
GL-CLASS	164		Seat/Door	HS - Seat heater																																	
GL-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
GL-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DCM-FR - Door control module front right			V																														

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
GL-CLASS	164		Seat/Door	DCM-FL - Door control module front left	V																																
GL-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GL-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
GL-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
GL-CLASS	166		Drive	SG-EM - Power electronics																																	
GL-CLASS	166		Drive	PTCU - Common powertrain controller																																	
GL-CLASS	166		Drive	ME/CDI/CNG - Engine control unit							V																						V				
GL-CLASS	166		Drive	ETC - Electronic transmission control																																	
GL-CLASS	166		Drive	VG - Transfer case																																	
GL-CLASS	166		Drive	SCR - Selective catalytic reduction																																	
GL-CLASS	166		Drive	ISM - Intelligent servo module																																	
GL-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	166		Drive	DTR - Distronic																																	
GL-CLASS	166		Chassis	ABS/ESP - Electronic stability program																				V	V												
GL-CLASS	166		Chassis	Suspension																																	
GL-CLASS	166		Chassis	ES - Electrical power steering																																	
GL-CLASS	166		Chassis	EFB - Electric parking brake										V																							
GL-CLASS	166		Chassis	FWGW - Chassis gateway																																	
GL-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
GL-CLASS	166		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
GL-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
GL-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
GL-CLASS	166		Body	Multifunction control unit																																	
GL-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
GL-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GL-CLASS	166		Body	AHE - Trailer recognition																																	
GL-CLASS	166		Body	AB - Airbag																																	
GL-CLASS	166		Information	Sound generator for exhaust system																																	
GL-CLASS	166		Information	Head-up display																																	
GL-CLASS	166		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
GL-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GL-CLASS	166		Information	ZAN - Audio/COMAND display																																	
GL-CLASS	166		Information	TV - TV tuner																																	
GL-CLASS	166		Information	SOUND - Sound system																																	
GL-CLASS	166		Information	SGR - Radar sensors control unit																																	
GL-CLASS	166		Information	360' - Camera																																	
GL-CLASS	166		Information	RFK - Backup camera																																	
GL-CLASS	166		Information	MFK - Multifunction camera																																	
GL-CLASS	166		Information	PTS - Parktronic system																																	
GL-CLASS	166		Information	NSA - Night View Assist																																	
GL-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	166		Information	NBR-RF - Right front range radar																																	
GL-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	166		Information	NBR-LF - Left front range radar																																	
GL-CLASS	166		Information	NAV - Navigation module																																	
GL-CLASS	166		Information	MIF/UCI - Media interface																																	
GL-CLASS	166		Information	IC - Instrument cluster																																	
GL-CLASS	166		Information	DVD player																																	
GL-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GL-CLASS	166		Information	AUDIO/COMAND												V						V															
GL-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
GL-CLASS	166		Seat/Door	HKS - Tailgate control																																	
GL-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
GL-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
GL-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
GL-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
GL-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
GL-CLASS	166		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	163		Drive	ME/CDI/CNG - Engine control unit									V																					V	V	
M-CLASS	163		Drive	ETC - Electronic transmission control								V					V													V							
M-CLASS	163		Drive	ESM - Electronic selector module																																	
M-CLASS	163		Drive	VG - Transfer case																																	
M-CLASS	163		Chassis	ABS/ESP - Electronic stability program																			V		V												
M-CLASS	163		Chassis	VP - Vacuum pump brake booster																																	
M-CLASS	163		Chassis	BAS - Brake assist																																	
M-CLASS	163		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	163		Body	AB - Airbag																																	
M-CLASS	163		Body	AAM - All activity module																																	
M-CLASS	163		Information	PTS - Parktronic system																																	
M-CLASS	163		Information	IC - Instrument cluster																V																	
M-CLASS	163		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	163		Information	AUDIO/COMAND																																	
M-CLASS	163		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	163		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Drive	ME/CDI/CNG - Engine control unit							V		V																		V		V	V	V		
M-CLASS	164		Drive	ETC - Electronic transmission control																																	
M-CLASS	164		Drive	VG - Transfer case																																	
M-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
M-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
M-CLASS	164		Drive	SCR - Selective catalytic reduction																																	
M-CLASS	164		Drive	ISM - Intelligent servo module																																	
M-CLASS	164		Drive	HSG - Hybrid control unit										V																							
M-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
M-CLASS	164		Drive	DTR - Distronic																																	
M-CLASS	164		Chassis	ABS/ESP - Electronic stability program																			V		V												
M-CLASS	164		Chassis	Suspension																																	
M-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
M-CLASS	164		Chassis	ES - Electrical power steering																																	
M-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	164		Body	WSS - Weight sensing system					V																												
M-CLASS	164		Body	UCP - Upper control panel																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
M-CLASS	164		Body	System diagnosis																																	
M-CLASS	164		Body	SCM [MRM] - Steering column module																																	
M-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V																													
M-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	OCP - Overhead control panel																																	
M-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
M-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	164		Body	CGW - Central gateway																																	
M-CLASS	164		Body	AB - Airbag																																	
M-CLASS	164		Information	TV - TV tuner																																	
M-CLASS	164		Information	SOUND - Sound system																																	
M-CLASS	164		Information	RFK - Backup camera																																	
M-CLASS	164		Information	PTS - Parktronic system																																	
M-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	164		Information	NAV - Navigation module																																	
M-CLASS	164		Information	MIF/UCI - Media interface																																	
M-CLASS	164		Information	IC - Instrument cluster						V																											
M-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
M-CLASS	164		Information	CM - Compass module																																	
M-CLASS	164		Information	AVE-H - Rear audio video unit																																	
M-CLASS	164		Information	AUDIO/COMAND																																	
M-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
M-CLASS	164		Information	ASSYST Active Service System						V																											
M-CLASS	164		Information	AGW - Audio gateway																																	
M-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
M-CLASS	164		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
M-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
M-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DCM-FR - Door control module front right			V																														
M-CLASS	164		Seat/Door	DCM-FL - Door control module front left	V																																
M-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
M-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	166		Drive	SG-EM - Power electronics																																	
M-CLASS	166		Drive	ME/CDI/CNG - Engine control unit							V																						V				
M-CLASS	166		Drive	ETC - Electronic transmission control																																	
M-CLASS	166		Drive	VG - Transfer case																																	
M-CLASS	166		Drive	SCR - Selective catalytic reduction																																	
M-CLASS	166		Drive	PTCU - Common powertrain controller																																	
M-CLASS	166		Drive	ISM - Intelligent servo module																																	
M-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	166		Drive	DTR - Distronic																																	
M-CLASS	166		Chassis	ABS/ESP - Electronic stability program																				V	V												
M-CLASS	166		Chassis	Suspension																																	
M-CLASS	166		Chassis	ES - Electrical power steering																																	
M-CLASS	166		Chassis	EFB - Electric parking brake										V																							
M-CLASS	166		Chassis	FWGW - Chassis gateway																																	
M-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
M-CLASS	166		Body	SCM [MRM] - Steering column module																																	
M-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
M-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
M-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
M-CLASS	166		Body	Multifunction control unit																																	
M-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
M-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
M-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
M-CLASS	166		Body	AHE - Trailer recognition																																	
M-CLASS	166		Body	AB - Airbag																																	
M-CLASS	166		Information	Sound generator for exhaust system																																	
M-CLASS	166		Information	Head-up display																																	
M-CLASS	166		Information	AVE-H - Rear audio video unit																																	
M-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
M-CLASS	166		Information	ZAN - Audio/COMAND display																																	
M-CLASS	166		Information	TV - TV tuner																																	
M-CLASS	166		Information	SOUND - Sound system																																	
M-CLASS	166		Information	SGR - Radar sensors control unit																																	
M-CLASS	166		Information	360' - Camera																																	
M-CLASS	166		Information	RFK - Backup camera																																	
M-CLASS	166		Information	MFK - Multifunction camera																																	
M-CLASS	166		Information	PTS - Parktronic system																																	
M-CLASS	166		Information	NSA - Night View Assist																																	
M-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	166		Information	NBR-RF - Right front range radar																																	
M-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	166		Information	NBR-LF - Left front range radar																																	
M-CLASS	166		Information	NAV - Navigation module																																	
M-CLASS	166		Information	MIF/UCI - Media interface																																	
M-CLASS	166		Information	IC - Instrument cluster																																	
M-CLASS	166		Information	DVD player																																	
M-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
M-CLASS	166		Information	AUDIO/COMAND												V						V															
M-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
M-CLASS	166		Seat/Door	HKS - Tailgate control																																	
M-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
M-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
M-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
M-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
M-CLASS	166		Air Conditioning	AAC - Automatic air conditioning																																	
R-CLASS	251		Drive	ME/CDI/CNG - Engine control unit							V		V																		V			V	V	V	
R-CLASS	251		Drive	ETC - Electronic transmission control																																	
R-CLASS	251		Drive	SCR - Selective catalytic reduction																																	
R-CLASS	251		Drive	ISM - Intelligent servo module																																	
R-CLASS	251		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
R-CLASS	251		Drive	DTR - Distronic																																	
R-CLASS	251		Chassis	ABS/ESP - Electronic stability program																			V		V												
R-CLASS	251		Chassis	Suspension																																	
R-CLASS	251		Chassis	ES - Electrical power steering																																	
R-CLASS	251		Chassis	TPM - Tire pressure monitor																																	
R-CLASS	251		Body	WSS - Weight sensing system					V																												
R-CLASS	251		Body	UCP - Upper control panel																																	
R-CLASS	251		Body	System diagnosis																																	
R-CLASS	251		Body	SCM [MRM] - Steering column module																																	
R-CLASS	251		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
R-CLASS	251		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V																													
R-CLASS	251		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	OCP - Overhead control panel																																	
R-CLASS	251		Body	LCP/HBF - Lower/Rear control panel																																	
R-CLASS	251		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
R-CLASS	251		Body	Headlamp-R - Headlamp control unit																																	
R-CLASS	251		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
R-CLASS	251		Body	EZS/EIS - Electronic ignition lock																																	
R-CLASS	251		Body	CGW - Central gateway																																	
R-CLASS	251		Body	AB - Airbag																																	
R-CLASS	251		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
R-CLASS	251		Information	SOUND - Sound system																																	
R-CLASS	251		Information	RFK - Backup camera																																	
R-CLASS	251		Information	PTS - Parktronic system																																	
R-CLASS	251		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
R-CLASS	251		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
R-CLASS	251		Information	NAV - Navigation module																																	
R-CLASS	251		Information	MIF/UCI - Media interface																																	
R-CLASS	251		Information	IC - Instrument cluster						V																											
R-CLASS	251		Information	DTA - Mbrace or TELEAID/GPS Box																																	
R-CLASS	251		Information	D-FOR - Display in right rear passenger																																	
R-CLASS	251		Information	D-FOL - Display in left rear passenger																																	
R-CLASS	251		Information	DAB/SDAR - Digital/Satellite radio																																	
R-CLASS	251		Information	CTEL/TEL - Cellular/Mobile telephone																																	
R-CLASS	251		Information	CM - Compass module																																	
R-CLASS	251		Information	AVE-H - Rear audio video unit																																	
R-CLASS	251		Information	AUDIO/COMAND																																	
R-CLASS	251		Information	ASSYST PLUS - PLUS Active Service System																																	
R-CLASS	251		Information	ASSYST Active Service System						V																											
R-CLASS	251		Information	AGW - Audio gateway																																	
R-CLASS	251		Seat/Door	REDC/RWT - Rear end door control module																																	
R-CLASS	251		Seat/Door	HS - Seat heater																																	
R-CLASS	251		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
R-CLASS	251		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
R-CLASS	251		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
R-CLASS	251		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DCM-FR - Door control module front right			V																														
R-CLASS	251		Seat/Door	DCM-FL - Door control module front left	V																																
R-CLASS	251		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
R-CLASS	251		Air Conditioning	AAC - Automatic air conditioning																																	
CLA-CLASS	117		Drive	VG - Transfer case																																	
CLA-CLASS	117		Drive	ME/CDI/CNG - Engine control unit							V																						V				
CLA-CLASS	117		Drive	ETC - Electronic transmission control																																	
CLA-CLASS	117		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLA-CLASS	117		Drive	DTR - Distronic																																	
CLA-CLASS	117		Drive	DSI - Direct select interface																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
CLA-CLASS	117		Drive	PTCU - Common powertrain controller																																	
CLA-CLASS	117		Chassis	ABS/ESP - Electronic stability program																																	
CLA-CLASS	117		Chassis	ES - Electrical power steering																																	
CLA-CLASS	117		Chassis	EFB - Electric parking brake										V																							
CLA-CLASS	117		Chassis	TPM - Tire pressure monitor																																	
CLA-CLASS	117		Body	SG-AWF - Collision prevention assist																																	
CLA-CLASS	117		Body	SCM [MRM] - Steering column module																																	
CLA-CLASS	117		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
CLA-CLASS	117		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
CLA-CLASS	117		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
CLA-CLASS	117		Body	Multifunction control unit																																	
CLA-CLASS	117		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
CLA-CLASS	117		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLA-CLASS	117		Body	EZS/EIS - Electronic ignition lock																																	
CLA-CLASS	117		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CLA-CLASS	117		Body	AHE - Trailer recognition																																	
CLA-CLASS	117		Body	AB - Airbag																																	
CLA-CLASS	117		Information	Head-up display																																	
CLA-CLASS	117		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLA-CLASS	117		Information	KAB - Camera cover																																	
CLA-CLASS	117		Information	ZAN - Audio/COMAND display																																	
CLA-CLASS	117		Information	TV - TV tuner																																	
CLA-CLASS	117		Information	SOUND - Sound system																																	
CLA-CLASS	117		Information	RFK - Backup camera																																	
CLA-CLASS	117		Information	MFK - Multifunction camera																																	
CLA-CLASS	117		Information	PTS - Parktronic system																																	
CLA-CLASS	117		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLA-CLASS	117		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLA-CLASS	117		Information	NAV - Navigation module																																	
CLA-CLASS	117		Information	MIF/UCI - Media interface																																	
CLA-CLASS	117		Information	IC - Instrument cluster																																	
CLA-CLASS	117		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLA-CLASS	117		Information	DAB/SDAR - Digital/Satellite radio																																	
CLA-CLASS	117		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLA-CLASS	117		Information	AUDIO/COMAND												V						V															
CLA-CLASS	117		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
CLA-CLASS	117		Seat/Door	PSD/MSC - Sliding roof control																																	
CLA-CLASS	117		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLA-CLASS	117		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLA-CLASS	117		Seat/Door	DCM-FR - Door control module front right																																	
CLA-CLASS	117		Seat/Door	DCM-FL - Door control module front left																																	
CLA-CLASS	117		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLA-CLASS	117		Air Conditioning	AAC - Automatic air conditioning																																	
CLK-CLASS	208		Drive	ME/CDI/CNG - Engine control unit											V																						
CLK-CLASS	208		Drive	ETC - Electronic transmission control								V					V													V							
CLK-CLASS	208		Drive	ESM - Electronic selector module																																	
CLK-CLASS	208		Chassis	PSE - Pneumatic system equipment																																	
CLK-CLASS	208		Chassis	ABS/ESP - Electronic stability program																					V												
CLK-CLASS	208		Chassis	VP - Vacuum pump brake booster																																	
CLK-CLASS	208		Chassis	BAS - Brake assist																																	
CLK-CLASS	208		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	208		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	208		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	208		Body	OCP - Overhead control panel																																	
CLK-CLASS	208		Body	AB - Airbag																																	
CLK-CLASS	208		Information	TV - TV tuner																																	
CLK-CLASS	208		Information	PTS - Parktronic system																																	
CLK-CLASS	208		Information	NAV - Navigation module																																	
CLK-CLASS	208		Information	IC - Instrument cluster						V										V																	
CLK-CLASS	208		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	208		Information	AUDIO/COMAND																																	
CLK-CLASS	208		Information	APS - Auto pilot system																																	
CLK-CLASS	208		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	208		Air Conditioning	AAC - Automatic air conditioning																																	
CLK-CLASS	208		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	208		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	208		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	208		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Drive	ME/CDI/CNG - Engine control unit									V																		V		V	V	V		
CLK-CLASS	209		Drive	ETC - Electronic transmission control													V													V							
CLK-CLASS	209		Drive	ESM - Electronic selector module																																	
CLK-CLASS	209		Drive	DTR - Distronic																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
CLK-CLASS	209		Chassis	ABS/ESP - Electronic stability program																			V		V												
CLK-CLASS	209		Chassis	TPM - Tire pressure monitor																																	
CLK-CLASS	209		Body	WSS - Weight sensing system					V																												
CLK-CLASS	209		Body	UCP - Upper control panel																																	
CLK-CLASS	209		Body	SCM [MRM] - Steering column module																																	
CLK-CLASS	209		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLK-CLASS	209		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V																													
CLK-CLASS	209		Body	RCM - Rear control module		V		V																													
CLK-CLASS	209		Body	OCP - Overhead control panel																																	
CLK-CLASS	209		Body	Multifunction control unit																																	
CLK-CLASS	209		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	209		Body	Headlamp-R - Headlamp control unit																																	
CLK-CLASS	209		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLK-CLASS	209		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	209		Body	BNS/BMS - Battery sensor																																	
CLK-CLASS	209		Body	AHE - Trailer recognition																																	
CLK-CLASS	209		Body	AB - Airbag																																	
CLK-CLASS	209		Information	TV - TV tuner																																	
CLK-CLASS	209		Information	PTS - Parktronic system																																	
CLK-CLASS	209		Information	NAV - Navigation module																																	
CLK-CLASS	209		Information	IC - Instrument cluster						V																											
CLK-CLASS	209		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	209		Information	AUDIO/COMAND																																	
CLK-CLASS	209		Information	AGW - Audio gateway																																	
CLK-CLASS	209		Seat/Door	RVC/VDS - Convertible roof control		V		V																													
CLK-CLASS	209		Seat/Door	REDC/RWT - Rear end door control module																																	
CLK-CLASS	209		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	209		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Seat/Door	DCM-FR - Door control module front right			V																														
CLK-CLASS	209		Seat/Door	DCM-FL - Door control module front left	V																																
CLK-CLASS	209		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	209		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	219		Drive	ME/CDI/CNG - Engine control unit									V																		V			V	V	V	
CLS-CLASS	219		Drive	ETC - Electronic transmission control													V													V							
CLS-CLASS	219		Drive	ESM - Electronic selector module																																	
CLS-CLASS	219		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
CLS-CLASS	219		Drive	DTR - Distronic																																	
CLS-CLASS	219		Chassis	ABS/ESP - Electronic stability program																			V		V												
CLS-CLASS	219		Chassis	Suspension																																	
CLS-CLASS	219		Chassis	SBC - Sensotronic Brake Control																																	
CLS-CLASS	219		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	219		Body	WSS - Weight sensing system					V																												
CLS-CLASS	219		Body	UCP - Upper control panel																																	
CLS-CLASS	219		Body	System diagnosis																																	
CLS-CLASS	219		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	219		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	219		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CLS-CLASS	219		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V																													
CLS-CLASS	219		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	OCP - Overhead control panel																																	
CLS-CLASS	219		Body	LCP/HBF - Lower/Rear control panel																																	
CLS-CLASS	219		Body	LAE [LAA] - Loading floor automatically extendable																																	
CLS-CLASS	219		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	219		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	219		Body	CGW - Central gateway																																	
CLS-CLASS	219		Body	BNS/BMS - Battery sensor																																	
CLS-CLASS	219		Body	AB - Airbag																																	
CLS-CLASS	219		Information	TV - TV tuner																																	
CLS-CLASS	219		Information	SOUND - Sound system																																	
CLS-CLASS	219		Information	PTS - Parktronic system																																	
CLS-CLASS	219		Information	MIF/UCI - Media interface																																	
CLS-CLASS	219		Information	IC - Instrument cluster						V																											
CLS-CLASS	219		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	219		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	219		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	219		Information	AUDIO/COMAND																																	
CLS-CLASS	219		Information	ASSYST PLUS - PLUS Active Service System																																	
CLS-CLASS	219		Information	ASSYST Active Service System						V																											
CLS-CLASS	219		Information	AGW - Audio gateway																																	
CLS-CLASS	219		Seat/Door	REDC/RWT - Rear end door control module																																	
CLS-CLASS	219		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
CLS-CLASS	219		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	219		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	219		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	219		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DCM-RR - Door control module rear right				V																													
CLS-CLASS	219		Seat/Door	DCM-RL - Door control module rear left		V																															
CLS-CLASS	219		Seat/Door	DCM-FR - Door control module front right			V																														
CLS-CLASS	219		Seat/Door	DCM-FL - Door control module front left	V																																
CLS-CLASS	219		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	219		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	218		Drive	ME/CDI/CNG - Engine control unit							V																				V			V	V		
CLS-CLASS	218		Drive	ETC - Electronic transmission control																																	
CLS-CLASS	218		Drive	ESM - Electronic selector module																																	
CLS-CLASS	218		Drive	SCR - Selective catalytic reduction																																	
CLS-CLASS	218		Drive	ISM - Intelligent servo module																																	
CLS-CLASS	218		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLS-CLASS	218		Drive	DTR - Distronic																																	
CLS-CLASS	218		Drive	DSI - Direct select interface																																	
CLS-CLASS	218		Drive	AMG DRIVE UNIT																																	
CLS-CLASS	218		Chassis	ABS/ESP - Electronic stability program																																	
CLS-CLASS	218		Chassis	Suspension																																	
CLS-CLASS	218		Chassis	ES - Electrical power steering																																	
CLS-CLASS	218		Chassis	FWGW - Chassis gateway																																	
CLS-CLASS	218		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	218		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
CLS-CLASS	218		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
CLS-CLASS	218		Body	WSS - Weight sensing system																																	
CLS-CLASS	218		Body	SG-AWF - Collision prevention assist																																	
CLS-CLASS	218		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	218		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	218		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
CLS-CLASS	218		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
CLS-CLASS	218		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
CLS-CLASS	218		Body	OCP - Overhead control panel																																	
CLS-CLASS	218		Body	Multifunction control unit																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
CLS-CLASS	218		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
CLS-CLASS	218		Body	HSW/LRH - Steering wheel heater																																	
CLS-CLASS	218		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
CLS-CLASS	218		Body	Headlamp-R - Headlamp control unit																																	
CLS-CLASS	218		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	218		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	218		Body	CGW - Central gateway																																	
CLS-CLASS	218		Body	AHE - Trailer recognition																																	
CLS-CLASS	218		Body	AB - Airbag																																	
CLS-CLASS	218		Information	360' - Camera																																	
CLS-CLASS	218		Information	AVE-H - Rear audio video unit																																	
CLS-CLASS	218		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLS-CLASS	218		Information	ZAN - Audio/COMAND display																																	
CLS-CLASS	218		Information	TV - TV tuner																																	
CLS-CLASS	218		Information	SOUND - Sound system																																	
CLS-CLASS	218		Information	SGR - Radar sensors control unit																																	
CLS-CLASS	218		Information	MFK - Multifunction camera																																	
CLS-CLASS	218		Information	RFK - Backup camera																																	
CLS-CLASS	218		Information	PTS - Parktronic system																																	
CLS-CLASS	218		Information	NSA - Night View Assist																																	
CLS-CLASS	218		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLS-CLASS	218		Information	NBR-RF - Right front range radar																																	
CLS-CLASS	218		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLS-CLASS	218		Information	NBR-LF - Left front range radar																																	
CLS-CLASS	218		Information	NAV - Navigation module																																	
CLS-CLASS	218		Information	MIF/UCI - Media interface																																	
CLS-CLASS	218		Information	ICI - InCar Internet																																	
CLS-CLASS	218		Information	IC - Instrument cluster																																	
CLS-CLASS	218		Information	DVD player																																	
CLS-CLASS	218		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	218		Information	D-FOR - Display in right rear passenger																																	
CLS-CLASS	218		Information	D-FOL - Display in left rear passenger																																	
CLS-CLASS	218		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	218		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	218		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLS-CLASS	218		Information	AUDIO/COMAND												V						V															

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
CLS-CLASS	218		Seat/Door	PSD/MSC - Sliding roof control																																	
CLS-CLASS	218		Seat/Door	HKS - Tailgate control																																	
CLS-CLASS	218		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	218		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	218		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	218		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	218		Seat/Door	DCM-RL - Door control module rear left																																	
CLS-CLASS	218		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	218		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	218		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	218		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	215		Drive	ME/CDI/CNG - Engine control unit											V																						
CL-CLASS	215		Drive	ETC - Electronic transmission control								V					V													V							
CL-CLASS	215		Drive	ESM - Electronic selector module																																	
CL-CLASS	215		Drive	DTR - Distronic																																	
CL-CLASS	215		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	215		Chassis	Suspension																																	
CL-CLASS	215		Chassis	PSE - Pneumatic system equipment																																	
CL-CLASS	215		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	215		Body	UCP - Upper control panel																																	
CL-CLASS	215		Body	System diagnosis																																	
CL-CLASS	215		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	215		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	215		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CL-CLASS	215		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	215		Body	RCM - Rear control module																																	
CL-CLASS	215		Body	OCP - Overhead control panel																																	
CL-CLASS	215		Body	Multifunction control unit																																	
CL-CLASS	215		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	215		Body	HSW/LRH - Steering wheel heater																																	
CL-CLASS	215		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	215		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	215		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	215		Body	CGW - Central gateway																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
CL-CLASS	215		Body	AHE - Trailer recognition																																	
CL-CLASS	215		Body	AB - Airbag																																	
CL-CLASS	215		Information	TV - TV tuner																																	
CL-CLASS	215		Information	PTS - Parktronic system																																	
CL-CLASS	215		Information	NAV - Navigation module																																	
CL-CLASS	215		Information	IC - Instrument cluster						V										V																	
CL-CLASS	215		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	215		Information	AUDIO/COMAND																																	
CL-CLASS	215		Information	AGW - Audio gateway																																	
CL-CLASS	215		Seat/Door	OSB-FR - Multicontour backrest front right																																	
CL-CLASS	215		Seat/Door	OSB-FL - Multicontour backrest front left																																	
CL-CLASS	215		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	215		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	215		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	215		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	215		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	215		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
CL-CLASS	215		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	216		Drive	ME/CDI/CNG - Engine control unit							V																				V		V	V			
CL-CLASS	216		Drive	ETC - Electronic transmission control													V													V							
CL-CLASS	216		Drive	ISM - Intelligent servo module																																	
CL-CLASS	216		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	216		Drive	DTR - Distronic																																	
CL-CLASS	216		Chassis	ABS/ESP - Electronic stability program																				V	V												
CL-CLASS	216		Chassis	Suspension																																	
CL-CLASS	216		Chassis	ES - Electrical power steering																																	
CL-CLASS	216		Chassis	EFB - Electric parking brake																																	
CL-CLASS	216		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	216		Body	WSS - Weight sensing system																																	
CL-CLASS	216		Body	UCP - Upper control panel																																	
CL-CLASS	216		Body	System diagnosis																																	
CL-CLASS	216		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	216		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	216		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	216		Body	RCM - Rear control module																																	
CL-CLASS	216		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
CL-CLASS	216		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
CL-CLASS	216		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	216		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	216		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	216		Body	CGW - Central gateway																																	
CL-CLASS	216		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	216		Body	AHE - Trailer recognition																																	
CL-CLASS	216		Body	AB - Airbag																																	
CL-CLASS	216		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	216		Information	VCS - Voice control																																	
CL-CLASS	216		Information	TV - TV tuner																																	
CL-CLASS	216		Information	Tuner - Standard tuner																																	
CL-CLASS	216		Information	SGR - Radar sensors control unit																																	
CL-CLASS	216		Information	MFK - Multifunction camera																																	
CL-CLASS	216		Information	RFK - Backup camera																																	
CL-CLASS	216		Information	PTS - Parktronic system																																	
CL-CLASS	216		Information	NSA - Night View Assist																																	
CL-CLASS	216		Information	NBR-LF - Left front range radar																																	
CL-CLASS	216		Information	NAV - Navigation module																																	
CL-CLASS	216		Information	MIF/UCI - Media interface																																	
CL-CLASS	216		Information	ICI - InCar Internet																																	
CL-CLASS	216		Information	IC - Instrument cluster																																	
CL-CLASS	216		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	216		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	216		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	216		Information	AUDIO/COMAND												V						V															
CL-CLASS	216		Information	ASSYST PLUS - PLUS Active Service System																																	
CL-CLASS	216		Information	ASSYST Active Service System																																	
CL-CLASS	216		Seat/Door	TLC/GTO - Garage door opener																																	
CL-CLASS	216		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	216		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	216		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	216		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	216		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
CL-CLASS	216		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	216		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	216		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	217		Drive	SCR - Selective catalytic reduction																																	
CL-CLASS	217		Drive	SG-EM - Power electronics																																	
CL-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	217		Drive	DTR - Distronic																																	
CL-CLASS	217		Drive	ISM - Intelligent servo module																																	
CL-CLASS	217		Drive	ME/CDI/CNG - Engine control unit							V																						V				
CL-CLASS	217		Drive	ETC - Electronic transmission control																																	
CL-CLASS	217		Drive	PTCU - Common powertrain controller																																	
CL-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	217		Chassis	ABS/ESP - Electronic stability program										V																							
CL-CLASS	217		Chassis	ES - Electrical power steering																																	
CL-CLASS	217		Chassis	Suspension																																	
CL-CLASS	217		Chassis	EFB - Electric parking brake																																	
CL-CLASS	217		Information	TPAD - Touchpad																																	
CL-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	217		Information	360' - Camera																																	
CL-CLASS	217		Information	SOUND - Sound system																																	
CL-CLASS	217		Information	RFK - Backup camera																																	
CL-CLASS	217		Information	SGR - Radar sensors control unit																																	
CL-CLASS	217		Information	PTS - Parktronic system																																	
CL-CLASS	217		Information	NSA - Night View Assist																																	
CL-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CL-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CL-CLASS	217		Information	NBR-RF - Right front range radar																																	
CL-CLASS	217		Information	NBR-LF - Left front range radar																																	
CL-CLASS	217		Information	MFK - Multifunction camera																																	
CL-CLASS	217		Information	Head-up display																																	
CL-CLASS	217		Information	AUDIO/COMAND																																	
CL-CLASS	217		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	217		Information	KAB - Camera cover																																	
CL-CLASS	217		Information	IC - Instrument cluster																																	
CL-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
CL-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CL-CLASS	217		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	AB - Airbag																																	
CL-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
CL-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
CL-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	217		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	217		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
CL-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
CL-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	170		Drive	ME/CDI/CNG - Engine control unit											V																						
SLK-CLASS	170		Drive	ETC - Electronic transmission control								V					V													V							
SLK-CLASS	170		Drive	ESM - Electronic selector module																																	
SLK-CLASS	170		Chassis	ABS/ESP - Electronic stability program																			V		V												
SLK-CLASS	170		Chassis	VP - Vacuum pump brake booster																																	
SLK-CLASS	170		Chassis	BAS - Brake assist																																	
SLK-CLASS	170		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	170		Body	AB - Airbag																																	
SLK-CLASS	170		Information	IC - Instrument cluster																V																	
SLK-CLASS	170		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	170		Information	AUDIO/COMAND																																	
SLK-CLASS	170		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
SLK-CLASS	170		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	171		Drive	ME/CDI/CNG - Engine control unit																											V			V	V		
SLK-CLASS	171		Drive	ETC - Electronic transmission control													V													V							
SLK-CLASS	171		Drive	ESM - Electronic selector module																																	
SLK-CLASS	171		Chassis	ABS/ESP - Electronic stability program																			V		V												
SLK-CLASS	171		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	171		Body	WSS - Weight sensing system					V																												
SLK-CLASS	171		Body	UCP - Upper control panel																																	
SLK-CLASS	171		Body	System diagnosis																																	
SLK-CLASS	171		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	171		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	171		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V																													
SLK-CLASS	171		Body	OCP - Overhead control panel																																	
SLK-CLASS	171		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	171		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	171		Body	CGW - Central gateway																																	
SLK-CLASS	171		Body	AB - Airbag																																	
SLK-CLASS	171		Information	TV - TV tuner																																	
SLK-CLASS	171		Information	SOUND - Sound system																																	
SLK-CLASS	171		Information	PTS - Parktronic system																																	
SLK-CLASS	171		Information	MIF/UCI - Media interface																																	
SLK-CLASS	171		Information	IC - Instrument cluster						V																											
SLK-CLASS	171		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	171		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	171		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SLK-CLASS	171		Information	AUDIO/COMAND																																	
SLK-CLASS	171		Information	ASSYST PLUS - PLUS Active Service System																																	
SLK-CLASS	171		Information	ASSYST Active Service System						V																											
SLK-CLASS	171		Information	AGW - Audio gateway																																	
SLK-CLASS	171		Seat/Door	RVC/VDS - Convertible roof control		V																															
SLK-CLASS	171		Seat/Door	HS - Seat heater																																	
SLK-CLASS	171		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	171		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	171		Seat/Door	DCM-FR - Door control module front right			V																														
SLK-CLASS	171		Seat/Door	DCM-FL - Door control module front left	V																																
SLK-CLASS	171		Air Conditioning	AAC - Automatic air conditioning																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
SLK-CLASS	172		Drive	ME/CDI/CNG - Engine control unit							V																							V			
SLK-CLASS	172		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	172		Drive	ESM - Electronic selector module																																	
SLK-CLASS	172		Drive	DTR - Distronic																																	
SLK-CLASS	172		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLK-CLASS	172		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	172		Chassis	Suspension																																	
SLK-CLASS	172		Chassis	ES - Electrical power steering																																	
SLK-CLASS	172		Chassis	EFB - Electric parking brake										V																							
SLK-CLASS	172		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	172		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	172		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	172		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
SLK-CLASS	172		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
SLK-CLASS	172		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
SLK-CLASS	172		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
SLK-CLASS	172		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLK-CLASS	172		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	172		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	172		Body	CGW - Central gateway																																	
SLK-CLASS	172		Body	AB - Airbag																																	
SLK-CLASS	172		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SLK-CLASS	172		Information	ZAN - Audio/COMAND display																																	
SLK-CLASS	172		Information	TV - TV tuner																																	
SLK-CLASS	172		Information	SOUND - Sound system																																	
SLK-CLASS	172		Information	SGR - Radar sensors control unit																																	
SLK-CLASS	172		Information	MFK - Multifunction camera																																	
SLK-CLASS	172		Information	PTS - Parktronic system																																	
SLK-CLASS	172		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLK-CLASS	172		Information	NBR-RF - Right front range radar																																	
SLK-CLASS	172		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLK-CLASS	172		Information	NBR-LF - Left front range radar																																	
SLK-CLASS	172		Information	NAV - Navigation module																																	
SLK-CLASS	172		Information	MIF/UCI - Media interface																																	
SLK-CLASS	172		Information	IC - Instrument cluster																																	
SLK-CLASS	172		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
SLK-CLASS	172		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	172		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLK-CLASS	172		Information	AUDIO/COMAND												V						V															
SLK-CLASS	172		Seat/Door	RVC/VDS - Convertible roof control																																	
SLK-CLASS	172		Seat/Door	PSD/MSC - Sliding roof control																																	
SLK-CLASS	172		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	172		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	172		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	172		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	172		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	129		Drive	ME/CDI/CNG - Engine control unit											V																						
SL-CLASS	129		Drive	ETC - Electronic transmission control								V																									
SL-CLASS	129		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	129		Chassis	BAS - Brake assist																																	
SL-CLASS	129		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	129		Body	AB - Airbag																																	
SL-CLASS	129		Information	NAV - Navigation module																																	
SL-CLASS	129		Information	IC - Instrument cluster						V										V																	
SL-CLASS	129		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	129		Information	AUDIO/COMAND																																	
SL-CLASS	129		Information	APS - Auto pilot system																																	
SL-CLASS	129		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	129		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	230		Drive	ME/CDI/CNG - Engine control unit																											V		V	V			
SL-CLASS	230		Drive	ETC - Electronic transmission control													V													V							
SL-CLASS	230		Drive	ESM - Electronic selector module																																	
SL-CLASS	230		Drive	DTR - Distronic																																	
SL-CLASS	230		Drive	AMG DRIVE UNIT																																	
SL-CLASS	230		Chassis	ABS/ESP - Electronic stability program																			V		V												
SL-CLASS	230		Chassis	Suspension																																	
SL-CLASS	230		Chassis	SBC - Sensotronic Brake Control																																	
SL-CLASS	230		Chassis	PSE - Pneumatic system equipment																																	
SL-CLASS	230		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	230		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	230		Body	WSS - Weight sensing system					V																												
SL-CLASS	230		Body	System diagnosis																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
SL-CLASS	230		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	230		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	230		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SL-CLASS	230		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	230		Body	OCP - Overhead control panel																																	
SL-CLASS	230		Body	LCP/HBF - Lower/Rear control panel																																	
SL-CLASS	230		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	230		Body	HSW/LRH - Steering wheel heater																																	
SL-CLASS	230		Body	Headlamp-R - Headlamp control unit																																	
SL-CLASS	230		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	230		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	230		Body	CGW - Central gateway																																	
SL-CLASS	230		Body	BNS/BMS - Battery sensor																																	
SL-CLASS	230		Body	AB - Airbag																																	
SL-CLASS	230		Information	TV - TV tuner																																	
SL-CLASS	230		Information	SOUND - Sound system																																	
SL-CLASS	230		Information	PTS - Parktronic system																																	
SL-CLASS	230		Information	MIF/UCI - Media interface																																	
SL-CLASS	230		Information	IC - Instrument cluster						V																											
SL-CLASS	230		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	230		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	230		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SL-CLASS	230		Information	AUDIO/COMAND																																	
SL-CLASS	230		Information	AGW - Audio gateway																																	
SL-CLASS	230		Seat/Door	RVC/VDS - Convertible roof control		V		V																													
SL-CLASS	230		Seat/Door	OSB-FR - Multicontour backrest front right																																	
SL-CLASS	230		Seat/Door	OSB-FL - Multicontour backrest front left																																	
SL-CLASS	230		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	230		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	230		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	230		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	230		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	230		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	231		Drive	ME/CDI/CNG - Engine control unit							V																						V				
SL-CLASS	231		Drive	ETC - Electronic transmission control																																	
SL-CLASS	231		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
SL-CLASS	231		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SL-CLASS	231		Drive	DTR - Distronic																																	
SL-CLASS	231		Drive	DSI - Direct select interface																																	
SL-CLASS	231		Drive	AMG DRIVE UNIT																																	
SL-CLASS	231		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	231		Chassis	Suspension																																	
SL-CLASS	231		Chassis	ES - Electrical power steering																																	
SL-CLASS	231		Chassis	EFB - Electric parking brake										V																							
SL-CLASS	231		Chassis	FWGW - Chassis gateway																																	
SL-CLASS	231		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	231		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	231		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	231		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
SL-CLASS	231		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
SL-CLASS	231		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
SL-CLASS	231		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
SL-CLASS	231		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	231		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	231		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	231		Body	CGW - Central gateway																																	
SL-CLASS	231		Body	AB - Airbag																																	
SL-CLASS	231		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SL-CLASS	231		Information	ZAN - Audio/COMAND display																																	
SL-CLASS	231		Information	TV - TV tuner																																	
SL-CLASS	231		Information	SOUND - Sound system																																	
SL-CLASS	231		Information	SGR - Radar sensors control unit																																	
SL-CLASS	231		Information	RFK - Backup camera																																	
SL-CLASS	231		Information	MFK - Multifunction camera																																	
SL-CLASS	231		Information	PTS - Parktronic system																																	
SL-CLASS	231		Information	NSA - Night View Assist																																	
SL-CLASS	231		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SL-CLASS	231		Information	NBR-RF - Right front range radar																																	
SL-CLASS	231		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SL-CLASS	231		Information	NBR-LF - Left front range radar																																	
SL-CLASS	231		Information	MIF/UCI - Media interface																																	
SL-CLASS	231		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
SL-CLASS	231		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	231		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	231		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SL-CLASS	231		Information	AUDIO/COMAND												V						V															
SL-CLASS	231		Information	AMG Performance Media																																	
SL-CLASS	231		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	231		Seat/Door	PSD/MSC - Sliding roof control																																	
SL-CLASS	231		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	231		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	231		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
SL-CLASS	231		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	231		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	231		Air Conditioning	AAC - Automatic air conditioning																																	
SLS-CLASS	197		Drive	PTCU - Common powertrain controller																																	
SLS-CLASS	197		Drive	ME/CDI/CNG - Engine control unit																											V		V	V			
SLS-CLASS	197		Drive	ETC - Electronic transmission control																																	
SLS-CLASS	197		Drive	ISM - Intelligent servo module																																	
SLS-CLASS	197		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLS-CLASS	197		Drive	DSI - Direct select interface																																	
SLS-CLASS	197		Drive	AMG DRIVE UNIT																																	
SLS-CLASS	197		Chassis	ABS/ESP - Electronic stability program																																	
SLS-CLASS	197		Chassis	Suspension																																	
SLS-CLASS	197		Chassis	ES - Electrical power steering																																	
SLS-CLASS	197		Chassis	EFB - Electric parking brake										V																							
SLS-CLASS	197		Chassis	TPM - Tire pressure monitor																																	
SLS-CLASS	197		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
SLS-CLASS	197		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
SLS-CLASS	197		Body	CSHV - Crash sensor/high-voltage battery																																	
SLS-CLASS	197		Body	BNS/BMS - Battery sensor							V																						V				
SLS-CLASS	197		Body	WSS - Weight sensing system																																	
SLS-CLASS	197		Body	SCM [MRM] - Steering column module																																	
SLS-CLASS	197		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLS-CLASS	197		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
SLS-CLASS	197		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
SLS-CLASS	197		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLS-CLASS	197		Body	EZS/EIS - Electronic ignition lock																																	
SLS-CLASS	197		Body	CGW - Central gateway																																	
SLS-CLASS	197		Body	AB - Airbag																																	
SLS-CLASS	197		Information	MFK - Multifunction camera																																	
SLS-CLASS	197		Information	SGR - Radar sensors control unit																																	
SLS-CLASS	197		Information	ZAN - Audio/COMAND display																																	
SLS-CLASS	197		Information	SOUND - Sound system																																	
SLS-CLASS	197		Information	PTS - Parktronic system																																	
SLS-CLASS	197		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLS-CLASS	197		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLS-CLASS	197		Information	MIF/UCI - Media interface																																	
SLS-CLASS	197		Information	IC - Instrument cluster																																	
SLS-CLASS	197		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLS-CLASS	197		Information	DAB/SDAR - Digital/Satellite radio																																	
SLS-CLASS	197		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLS-CLASS	197		Information	AUDIO/COMAND												V						V															
SLS-CLASS	197		Information	AMG Performance Media																																	
SLS-CLASS	197		Seat/Door	RVC/VDS - Convertible roof control																																	
SLS-CLASS	197		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLS-CLASS	197		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLS-CLASS	197		Seat/Door	DCM-FR - Door control module front right																																	
SLS-CLASS	197		Seat/Door	DCM-FL - Door control module front left																																	
SLS-CLASS	197		Air Conditioning	AAC - Automatic air conditioning																																	
AMG GT	190		Drive	DTR - Distronic																																	
AMG GT	190		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
AMG GT	190		Drive	DSI - Direct select interface																																	
AMG GT	190		Drive	AMG DRIVE UNIT																																	
AMG GT	190		Drive	PTCU - Common powertrain controller																																	
AMG GT	190		Drive	ME/CDI/CNG - Engine control unit							V																						V				
AMG GT	190		Drive	ETC - Electronic transmission control																																	
AMG GT	190		Chassis	TPM - Tire pressure monitor																																	
AMG GT	190		Chassis	Suspension																																	
AMG GT	190		Chassis	ABS/ESP - Electronic stability program																																	
AMG GT	190		Chassis	EFB - Electric parking brake										V																							
AMG GT	190		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
AMG GT	190		Information	DAB/SDAR - Digital/Satellite radio																																	
AMG GT	190		Information	SOUND - Sound system																																	
AMG GT	190		Information	RFK - Backup camera																																	
AMG GT	190		Information	PTS - Parktronic system																																	
AMG GT	190		Information	MFK - Multifunction camera																																	
AMG GT	190		Information	IC - Instrument cluster																																	
AMG GT	190		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
AMG GT	190		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
AMG GT	190		Information	AUDIO/COMAND																																	
AMG GT	190		Information	ZAN - Audio/COMAND display																																	
AMG GT	190		Information	COU [ZBE] - Audio/COMAND operating unit																																	
AMG GT	190		Information	DTA - Mbrace or TELEAID/GPS Box																																	
AMG GT	190		Information	AMG Performance Media																																	
AMG GT	190		Body	SCM [MRM] - Steering column module																																	
AMG GT	190		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
AMG GT	190		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
AMG GT	190		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
AMG GT	190		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
AMG GT	190		Body	AB - Airbag																																	
AMG GT	190		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
AMG GT	190		Body	Headlamp-R - Headlamp control unit																																	
AMG GT	190		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
AMG GT	190		Body	SG-AWF - Collision prevention assist																																	
AMG GT	190		Body	EZS/EIS - Electronic ignition lock																																	
AMG GT	190		Body	CGW - Central gateway																																	
AMG GT	190		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
AMG GT	190		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
AMG GT	190		Seat/Door	DCM-FR - Door control module front right																																	
AMG GT	190		Seat/Door	DCM-FL - Door control module front left																																	
AMG GT	190		Air Conditioning	AAC - Automatic air conditioning																																	
SLR-CLASS	199		Drive	ME/CDI/CNG - Engine control unit																																	
SLR-CLASS	199		Drive	ETC - Electronic transmission control													V													V							
SLR-CLASS	199		Drive	ESM - Electronic selector module																																	
SLR-CLASS	199		Chassis	ABS/ESP - Electronic stability program																					V												
SLR-CLASS	199		Chassis	SBC - Sensotronic Brake Control																																	
SLR-CLASS	199		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
SLR-CLASS	199		Body	WSS - Weight sensing system					V																												
SLR-CLASS	199		Body	SCM [MRM] - Steering column module																																	
SLR-CLASS	199		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLR-CLASS	199		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SLR-CLASS	199		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLR-CLASS	199		Body	OCP - Overhead control panel																																	
SLR-CLASS	199		Body	LCP/HBF - Lower/Rear control panel																																	
SLR-CLASS	199		Body	Headlamp-R - Headlamp control unit																																	
SLR-CLASS	199		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLR-CLASS	199		Body	EZS/EIS - Electronic ignition lock																																	
SLR-CLASS	199		Body	CGW - Central gateway																																	
SLR-CLASS	199		Body	BNS/BMS - Battery sensor																																	
SLR-CLASS	199		Body	AB - Airbag																																	
SLR-CLASS	199		Information	IC - Instrument cluster						V																											
SLR-CLASS	199		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLR-CLASS	199		Information	AUDIO/COMAND																																	
SLR-CLASS	199		Seat/Door	DCM-FR - Door control module front right																																	
SLR-CLASS	199		Seat/Door	DCM-FL - Door control module front left																																	
SLR-CLASS	199		Air Conditioning	AAC - Automatic air conditioning																																	
MAYBACH	240		Drive	ME/CDI/CNG - Engine control unit																											V		V	V			
MAYBACH	240		Drive	ETC - Electronic transmission control													V													V								
MAYBACH	240		Drive	ESM - Electronic selector module																																	
MAYBACH	240		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
MAYBACH	240		Drive	DTR - Distronic																																	
MAYBACH	240		Chassis	ABS/ESP - Electronic stability program																					V												
MAYBACH	240		Chassis	Suspension																																	
MAYBACH	240		Chassis	SBC - Sensotronic Brake Control																																	
MAYBACH	240		Chassis	TPM - Tire pressure monitor																																	
MAYBACH	240		Body	WSS - Weight sensing system					V																												
MAYBACH	240		Body	System diagnosis																																	
MAYBACH	240		Body	SCM [MRM] - Steering column module																																	
MAYBACH	240		Body	HSW/LRH - Steering wheel heater																																	
MAYBACH	240		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
MAYBACH	240		Body	AB - Airbag																																	
MAYBACH	240		Information	TV - TV tuner																																	
MAYBACH	240		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
MAYBACH	240		Information	DTA - Mbrace or TELEAID/GPS Box																																	
MAYBACH	240		Information	AGW - Audio gateway																																	
MAYBACH	240		Seat/Door	REDC/RWT - Rear end door control module																																	
MAYBACH	240		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All_Model(BETA)	16P Connector		Drive	SG-EM - Power electronics																																	
All_Model(BETA)	16P Connector		Drive	HFPM - Haptic accelerator pedal module																																	
All_Model(BETA)	16P Connector		Drive	ME/CDI/CNG - Engine control unit							V		V		V																V		V	V	V		
All_Model(BETA)	16P Connector		Drive	ETC - Electronic transmission control								V					V													V							
All_Model(BETA)	16P Connector		Drive	ESM - Electronic selector module																																	
All_Model(BETA)	16P Connector		Drive	VG - Transfer case																																	
All_Model(BETA)	16P Connector		Drive	VECU - Power monitoring control unit																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-B - Electric motor control unit B																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-A - Electric motor control unit A																																	
All_Model(BETA)	16P Connector		Drive	SCR - Selective catalytic reduction																																	
All_Model(BETA)	16P Connector		Drive	PTCU - Common powertrain controller																																	
All_Model(BETA)	16P Connector		Drive	Natural gas control unit																																	
All_Model(BETA)	16P Connector		Drive	ISM - Intelligent servo module																																	
All_Model(BETA)	16P Connector		Drive	Hydrogen tank control unit																																	
All_Model(BETA)	16P Connector		Drive	HSG - Hybrid control unit										V																							
All_Model(BETA)	16P Connector		Drive	High-temperature coolant pump control unit																																	
All_Model(BETA)	16P Connector		Drive	Fuel cell control unit																																	
All_Model(BETA)	16P Connector		Drive	FSCU-R - Control unit fuel pump																																	
All_Model(BETA)	16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
All_Model(BETA)	16P Connector		Drive	EMPI - Electronic Motor Pump Inverter																																	
All_Model(BETA)	16P Connector		Drive	Electric drive control unit																																	
All_Model(BETA)	16P Connector		Drive	DTR - Distronic																																	
All_Model(BETA)	16P Connector		Drive	DSI - Direct select interface																																	
All_Model(BETA)	16P Connector		Drive	Compressed Natural Gas Control Module																																	
All_Model(BETA)	16P Connector		Drive	CC - Cruise control																																	
All_Model(BETA)	16P Connector		Drive	BSA - Belt-driven starter/alternator																																	
All_Model(BETA)	16P Connector		Drive	AMG DRIVE UNIT																																	
All_Model(BETA)	16P Connector		Drive	ACS - Automatic clutch system																																	
All_Model(BETA)	16P Connector		Chassis	ABS/ESP - Electronic stability program																			V	V	V												
All_Model(BETA)	16P Connector		Chassis	Suspension																																	
All_Model(BETA)	16P Connector		Chassis	SBC - Sensotronic Brake Control																																	
All_Model(BETA)	16P Connector		Chassis	PSE - Pneumatic system equipment																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
All_Model(BETA)	16P Connector		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
All_Model(BETA)	16P Connector		Chassis	HAQ - Interwheel differential lock at rear axle																																	
All_Model(BETA)	16P Connector		Chassis	FWGW - Chassis gateway																																	
All_Model(BETA)	16P Connector		Chassis	ES - Electrical power steering																																	
All_Model(BETA)	16P Connector		Chassis	EFB - Electric parking brake										V																							
All_Model(BETA)	16P Connector		Chassis	BAS - Brake assist																																	
All_Model(BETA)	16P Connector		Chassis	VP - Vacuum pump brake booster																																	
All_Model(BETA)	16P Connector		Chassis	TPM - Tire pressure monitor																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
All_Model(BETA)	16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
All_Model(BETA)	16P Connector		Body	CSHV - Crash sensor/high-voltage battery																																	
All_Model(BETA)	16P Connector		Body	WSS - Weight sensing system					V																												
All_Model(BETA)	16P Connector		Body	UCP - Upper control panel																																	
All_Model(BETA)	16P Connector		Body	System diagnosis																																	
All_Model(BETA)	16P Connector		Body	SG-DDW - DC/DC converter control unit																																	
All_Model(BETA)	16P Connector		Body	SG-AWF - Collision prevention assist																																	
All_Model(BETA)	16P Connector		Body	SCM [MRM] - Steering column module																																	
All_Model(BETA)	16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
All_Model(BETA)	16P Connector		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
All_Model(BETA)	16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V													V																
All_Model(BETA)	16P Connector		Body	RevETR-RF - Right front reversible emergency tensioning retractor														V																			
All_Model(BETA)	16P Connector		Body	RevETR-LF - Left front reversible emergency tensioning retractor														V																			
All_Model(BETA)	16P Connector		Body	RCM - Rear control module		V		V																													
All_Model(BETA)	16P Connector		Body	OCP - Overhead control panel																																	
All_Model(BETA)	16P Connector		Body	Multifunction control unit																																	
All_Model(BETA)	16P Connector		Body	LCP/HBF - Lower/Rear control panel																																	
All_Model(BETA)	16P Connector		Body	LAE [LAA] - Loading floor automatically extendable																																	
All_Model(BETA)	16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	V
All_Model(BETA)	16P Connector		Body	HSW/LRH - Steering wheel heater																																	
All_Model(BETA)	16P Connector		Body	Headlamp-R - Headlamp control unit																																	
All_Model(BETA)	16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
All_Model(BETA)	16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
All_Model(BETA)	16P Connector		Body	CGW - Central gateway																																	
All_Model(BETA)	16P Connector		Body	BNS/BMS - Battery sensor																																	
All_Model(BETA)	16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
All_Model(BETA)	16P Connector		Body	AHE - Trailer recognition																																	
All_Model(BETA)	16P Connector		Body	AB - Airbag																																	
All_Model(BETA)	16P Connector		Body	AAM - All activity module																																	
All_Model(BETA)	16P Connector		Information	TPAD - Touchpad																																	
All_Model(BETA)	16P Connector		Information	Head-up display																																	
All_Model(BETA)	16P Connector		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
All_Model(BETA)	16P Connector		Information	KAB - Camera cover																																	
All_Model(BETA)	16P Connector		Information	ZAN - Audio/COMAND display																																	
All_Model(BETA)	16P Connector		Information	VCS - Voice control																																	
All_Model(BETA)	16P Connector		Information	TV - TV tuner																																	
All_Model(BETA)	16P Connector		Information	Tuner - Standard tuner																																	
All_Model(BETA)	16P Connector		Information	Sound generator for exhaust system																																	
All_Model(BETA)	16P Connector		Information	SOUND - Sound system																																	
All_Model(BETA)	16P Connector		Information	SGR - Radar sensors control unit																																	
All_Model(BETA)	16P Connector		Information	360' - Camera																																	
All_Model(BETA)	16P Connector		Information	MFK - Multifunction camera																																	
All_Model(BETA)	16P Connector		Information	RFK - Backup camera																																	
All_Model(BETA)	16P Connector		Information	PTS - Parktronic system																																	
All_Model(BETA)	16P Connector		Information	NSA - Night View Assist																																	
All_Model(BETA)	16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-RF - Right front range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LF - Left front range radar																																	
All_Model(BETA)	16P Connector		Information	NAV - Navigation module																																	
All_Model(BETA)	16P Connector		Information	MIF/UCI - Media interface																																	
All_Model(BETA)	16P Connector		Information	ICI - InCar Internet																																	
All_Model(BETA)	16P Connector		Information	IC - Instrument cluster						V										V																	
All_Model(BETA)	16P Connector		Information	DVD player																																	
All_Model(BETA)	16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
All_Model(BETA)	16P Connector		Information	D-FOR - Display in right rear passenger																																	
All_Model(BETA)	16P Connector		Information	D-FOL - Display in left rear passenger																																	
All_Model(BETA)	16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
All_Model(BETA)	16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
All_Model(BETA)	16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
All_Model(BETA)	16P Connector		Information	CM - Compass module																																	
All_Model(BETA)	16P Connector		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classfication	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search
All Model(BETA)	16P Connector		Information	AUDIO/COMAND												V						V															
All Model(BETA)	16P Connector		Information	ASSYST PLUS - PLUS Active Service System																																	
All Model(BETA)	16P Connector		Information	ASSYST Active Service System						V																											
All Model(BETA)	16P Connector		Information	APS - Auto pilot system																																	
All Model(BETA)	16P Connector		Information	AMG Performance Media																																	
All Model(BETA)	16P Connector		Information	AGW - Audio gateway																																	
All Model(BETA)	16P Connector		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-MR - Right center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-ML - Left center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TLC/GTO - Garage door opener																																	
All Model(BETA)	16P Connector		Seat/Door	RVC/VDS - Convertible roof control		V		V																													
All Model(BETA)	16P Connector		Seat/Door	REDC/RWT - Rear end door control module																																	
All Model(BETA)	16P Connector		Seat/Door	PSD/MSC - Sliding roof control																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-R - Multicontour backrest rear																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FR - Multicontour backrest front right																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FL - Multicontour backrest front left																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	HS - Seat heater																																	
All Model(BETA)	16P Connector		Seat/Door	HKS - Tailgate control																																	
All Model(BETA)	16P Connector		Seat/Door	ESA-R - Electric seat adjustment rear																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
All Model(BETA)	16P Connector		Seat/Door	ERA - Electric fold down backrest system																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-RR - Door control module rear right		V		V																													
All Model(BETA)	16P Connector		Seat/Door	DCM-RL - Door control module rear left		V																															
All Model(BETA)	16P Connector		Seat/Door	DCM-FR - Door control module front right			V																														
All Model(BETA)	16P Connector		Seat/Door	DCM-FL - Door control module front left	V																																
All Model(BETA)	16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All Model(BETA)	16P Connector		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
All Model(BETA)	16P Connector		Air Conditioning	HBF - Rear control panel																																	
All Model(BETA)	16P Connector		Air Conditioning	HB - Heater booster																																	
All Model(BETA)	16P Connector		Air Conditioning	EKMK - Electric refrigerant compressor																																	
All Model(BETA)	16P Connector		Air Conditioning	AAC - Automatic air conditioning																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
A-CLASS	68		Drive	ME/CDI/CNG - Engine control unit																																	
A-CLASS	68		Drive	ETC - Electronic transmission control						V	V	V																									
A-CLASS	68		Drive	ESM - Electronic selector module																																	
A-CLASS	68		Drive	ACS - Automatic clutch system																																	
A-CLASS	68		Chassis	ABS/ESP - Electronic stability program					V																												
A-CLASS	168		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Body	LCP/HBF - Lower/Rear control panel																																	
A-CLASS	168		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	168		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	168		Body	AB - Airbag																																	
A-CLASS	168		Information	PTS - Parktronic system																																	
A-CLASS	168		Information	IC - Instrument cluster																			V														
A-CLASS	168		Information	AUDIO/COMAND																																	
A-CLASS	168		Information	APS - Auto pilot system																																	
A-CLASS	168		Seat/Door	DCM-RR - Door control module rear right																																	
A-CLASS	168		Seat/Door	DCM-RL - Door control module rear left																																	
A-CLASS	168		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	168		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	168		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	168		Air Conditioning	HB - Heater booster																																	
A-CLASS	168		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	169		Drive	ME/CDI/CNG - Engine control unit			V	V																													
A-CLASS	169		Drive	ETC - Electronic transmission control																																	
A-CLASS	169		Drive	ESM - Electronic selector module																																	
A-CLASS	169		Drive	BSA - Belt-driven starter/alternator																																	
A-CLASS	169		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	169		Chassis	ES - Electrical power steering																																	
A-CLASS	169		Body	SCM [MRM] - Steering column module																																	
A-CLASS	169		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side															V																		
A-CLASS	169		Body	OCP - Overhead control panel																																	
A-CLASS	169		Body	Multifunction control unit																																	
A-CLASS	169		Body	Headlamp-R - Headlamp control unit																																	
A-CLASS	169		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
A-CLASS	169		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	169		Body	CGW - Central gateway																																	
A-CLASS	169		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
A-CLASS	169		Body	AHE - Trailer recognition																																	
A-CLASS	169		Body	AB - Airbag																																	
A-CLASS	169		Information	SOUND - Sound system																																	
A-CLASS	169		Information	PTS - Parktronic system																																	
A-CLASS	169		Information	MIF/UCI - Media interface																																	
A-CLASS	169		Information	IC - Instrument cluster																				V													
A-CLASS	169		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	169		Information	CTEL/TEL - Cellular/Mobile telephone																																	
A-CLASS	169		Information	AUDIO/COMAND																																	
A-CLASS	169		Information	ASSYST PLUS - PLUS Active Service System																																	
A-CLASS	169		Information	ASSYST Active Service System																				V													
A-CLASS	169		Information	AGW - Audio gateway																																	
A-CLASS	169		Seat/Door	DCM-RR - Door control module rear right																																	
A-CLASS	169		Seat/Door	DCM-RL - Door control module rear left																																	
A-CLASS	169		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	169		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	169		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	176		Drive	VG - Transfer case																																	
A-CLASS	176		Drive	ME/CDI/CNG - Engine control unit				V																													
A-CLASS	176		Drive	ETC - Electronic transmission control																																	
A-CLASS	176		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
A-CLASS	176		Drive	DTR - Distronic																																	
A-CLASS	176		Drive	DSI - Direct select interface																																	
A-CLASS	176		Drive	PTCU - Common powertrain controller																																	
A-CLASS	176		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	176		Chassis	ES - Electrical power steering																																	
A-CLASS	176		Chassis	EFB - Electric parking brake														V				V															
A-CLASS	176		Chassis	TPM - Tire pressure monitor																																	
A-CLASS	176		Body	SG-AWF - Collision prevention assist																																	
A-CLASS	176		Body	SCM [MRM] - Steering column module																																	
A-CLASS	176		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
A-CLASS	176		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	Multifunction control unit																																	
A-CLASS	176		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
A-CLASS	176		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
A-CLASS	176		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	176		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	176		Body	AHE - Trailer recognition																																	
A-CLASS	176		Body	AB - Airbag																																	
A-CLASS	176		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
A-CLASS	176		Information	ZAN - Audio/COMAND display																																	
A-CLASS	176		Information	TV - TV tuner																																	
A-CLASS	176		Information	SOUND - Sound system																																	
A-CLASS	176		Information	RFK - Backup camera																																	
A-CLASS	176		Information	MFK - Multifunction camera																																	
A-CLASS	176		Information	PTS - Parktronic system																																	
A-CLASS	176		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
A-CLASS	176		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
A-CLASS	176		Information	NAV - Navigation module																																	
A-CLASS	176		Information	MIF/UCI - Media interface																																	
A-CLASS	176		Information	IC - Instrument cluster																																	
A-CLASS	176		Information	DTA - Mbrace or TELEAID/GPS Box																																	
A-CLASS	176		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	176		Information	COU [ZBE] - Audio/COMAND operating unit																																	
A-CLASS	176		Information	AUDIO/COMAND																																	
A-CLASS	176		Seat/Door	PSD/MSC - Sliding roof control																																	
A-CLASS	176		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
A-CLASS	176		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
A-CLASS	176		Seat/Door	DCM-FR - Door control module front right																					V			V								V	
A-CLASS	176		Seat/Door	DCM-FL - Door control module front left																					V			V								V	
A-CLASS	176		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	176		Air Conditioning	AAC - Automatic air conditioning																						V											
B-CLASS	245		Drive	ME/CDI/CNG - Engine control unit			V	V																													
B-CLASS	245		Drive	ETC - Electronic transmission control																																	
B-CLASS	245		Drive	ESM - Electronic selector module																																	
B-CLASS	245		Drive	Hydrogen tank control unit																																	
B-CLASS	245		Drive	High-temperature coolant pump control unit																																	
B-CLASS	245		Drive	Fuel cell control unit																																	
B-CLASS	245		Drive	Electric drive control unit																																	
B-CLASS	245		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	245		Drive	BSA - Belt-driven starter/alternator																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
B-CLASS	245		Drive	VECU - Power monitoring control unit																																	
B-CLASS	245		Chassis	ABS/ESP - Electronic stability program																																	
B-CLASS	245		Chassis	ES - Electrical power steering																																	
B-CLASS	245		Chassis	VP - Vacuum pump brake booster																																	
B-CLASS	245		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	245		Body	WSS - Weight sensing system																																	
B-CLASS	245		Body	SG-DDW - DC/DC converter control unit																																	
B-CLASS	245		Body	SCM [MRM] - Steering column module																																	
B-CLASS	245		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																V																	
B-CLASS	245		Body	OCP - Overhead control panel																																	
B-CLASS	245		Body	Multifunction control unit																																	
B-CLASS	245		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	245		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	245		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	245		Body	CGW - Central gateway																																	
B-CLASS	245		Body	BNS/BMS - Battery sensor																																	
B-CLASS	245		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	245		Body	AHE - Trailer recognition																																	
B-CLASS	245		Body	AB - Airbag																																	
B-CLASS	245		Information	SOUND - Sound system																																	
B-CLASS	245		Information	PTS - Parktronic system																																	
B-CLASS	245		Information	NAV - Navigation module																																	
B-CLASS	245		Information	MIF/UCI - Media interface																																	
B-CLASS	245		Information	IC - Instrument cluster																				V													
B-CLASS	245		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	245		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	245		Information	CTEL/TEL - Cellular/Mobile telephone																																	
B-CLASS	245		Information	CM - Compass module																																	
B-CLASS	245		Information	AUDIO/COMAND																																	
B-CLASS	245		Information	ASSYST PLUS - PLUS Active Service System																																	
B-CLASS	245		Information	ASSYST Active Service System																				V													
B-CLASS	245		Information	AGW - Audio gateway																																	
B-CLASS	245		Seat/Door	DCM-RR - Door control module rear right																																	
B-CLASS	245		Seat/Door	DCM-RL - Door control module rear left																																	
B-CLASS	245		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	245		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
B-CLASS	245		Air Conditioning	EKMK - Electric refrigerant compressor																																	
B-CLASS	245		Air Conditioning	AAC - Automatic air conditioning																																	
B-CLASS	246		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	246		Drive	VG - Transfer case																																	
B-CLASS	246		Drive	ME/CDI/CNG - Engine control unit				V																													
B-CLASS	246		Drive	ETC - Electronic transmission control																																	
B-CLASS	246		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
B-CLASS	246		Drive	DTR - Distronic																																	
B-CLASS	246		Drive	PTCU - Common powertrain controller																																	
B-CLASS	246		Chassis	ABS/ESP - Electronic stability program																																	
B-CLASS	246		Chassis	ES - Electrical power steering																																	
B-CLASS	246		Chassis	EFB - Electric parking brake														V				V															
B-CLASS	246		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	246		Body	BNS/BMS - Battery sensor																																	
B-CLASS	246		Body	SG-AWF - Collision prevention assist																																	
B-CLASS	246		Body	SCM [MRM] - Steering column module																																	
B-CLASS	246		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
B-CLASS	246		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	Multifunction control unit																																	
B-CLASS	246		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
B-CLASS	246		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	246		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	246		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	246		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	246		Body	AHE - Trailer recognition																																	
B-CLASS	246		Body	AB - Airbag																																	
B-CLASS	246		Information	Sound generator for exhaust system																																	
B-CLASS	246		Information	Head-up display																																	
B-CLASS	246		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
B-CLASS	246		Information	ZAN - Audio/COMAND display																																	
B-CLASS	246		Information	TV - TV tuner																																	
B-CLASS	246		Information	SOUND - Sound system																																	
B-CLASS	246		Information	RFK - Backup camera																																	
B-CLASS	246		Information	MFK - Multifunction camera																																	
B-CLASS	246		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
B-CLASS	246		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
B-CLASS	246		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
B-CLASS	246		Information	NAV - Navigation module																																	
B-CLASS	246		Information	MIF/UCI - Media interface																																	
B-CLASS	246		Information	IC - Instrument cluster																																	
B-CLASS	246		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	246		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	246		Information	COU [ZBE] - Audio/COMAND operating unit																																	
B-CLASS	246		Information	AUDIO/COMAND																																	
B-CLASS	246		Seat/Door	PSD/MSC - Sliding roof control																																	
B-CLASS	246		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
B-CLASS	246		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
B-CLASS	246		Seat/Door	DCM-FR - Door control module front right																					V			V								V	
B-CLASS	246		Seat/Door	DCM-FL - Door control module front left																					V			V								V	
B-CLASS	246		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
B-CLASS	246		Air Conditioning	AAC - Automatic air conditioning																						V											
C-CLASS	202		Drive	ME/CDI/CNG - Engine control unit																																	
C-CLASS	202		Drive	ETC - Electronic transmission control						V	V	V																									
C-CLASS	202		Drive	ESM - Electronic selector module																																	
C-CLASS	202		Chassis	PSE - Pneumatic system equipment																																	
C-CLASS	202		Chassis	ABS/ESP - Electronic stability program					V																												
C-CLASS	202		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	202		Chassis	BAS - Brake assist																																	
C-CLASS	202		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	202		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	202		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	202		Body	OCP - Overhead control panel																																	
C-CLASS	202		Body	AB - Airbag																																	
C-CLASS	202		Information	PTS - Parktronic system																																	
C-CLASS	202		Information	NAV - Navigation module																																	
C-CLASS	202		Information	IC - Instrument cluster																			V														
C-CLASS	202		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	202		Information	AUDIO/COMAND																																	
C-CLASS	202		Information	APS - Auto pilot system																																	
C-CLASS	202		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	202		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
C-CLASS	202		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	202		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	202		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	202		Air Conditioning	HB - Heater booster																																	
C-CLASS	202		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	203		Drive	ME/CDI/CNG - Engine control unit			V	V																													
C-CLASS	203		Drive	ETC - Electronic transmission control						V	V	V																									
C-CLASS	203		Drive	ESM - Electronic selector module																																	
C-CLASS	203		Drive	DTR - Distronic																																	
C-CLASS	203		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	203		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	203		Chassis	BAS - Brake assist																																	
C-CLASS	203		Body	WSS - Weight sensing system																																	
C-CLASS	203		Body	UCP - Upper control panel																																	
C-CLASS	203		Body	System diagnosis																																	
C-CLASS	203		Body	SCM [MRM] - Steering column module																																	
C-CLASS	203		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	203		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																V																		
C-CLASS	203		Body	OCP - Overhead control panel																																	
C-CLASS	203		Body	Multifunction control unit																																	
C-CLASS	203		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	203		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	203		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	203		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	203		Body	CGW - Central gateway																																	
C-CLASS	203		Body	AHE - Trailer recognition																																	
C-CLASS	203		Body	AB - Airbag																																	
C-CLASS	203		Information	TV - TV tuner																																	
C-CLASS	203		Information	SOUND - Sound system																																	
C-CLASS	203		Information	PTS - Parktronic system																																	
C-CLASS	203		Information	NAV - Navigation module																																	
C-CLASS	203		Information	MIF/UCI - Media interface																																	
C-CLASS	203		Information	IC - Instrument cluster																				V													
C-CLASS	203		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	203		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	203		Information	CTEL/TEL - Cellular/Mobile telephone																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
C-CLASS	203		Information	AUDIO/COMAND																																	
C-CLASS	203		Information	AGW - Audio gateway																																	
C-CLASS	203		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	203		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	203		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	203		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	203		Seat/Door	DCM-FR - Door control module front right																V																	
C-CLASS	203		Seat/Door	DCM-FL - Door control module front left																V																	
C-CLASS	203		Air Conditioning	TSTH/STH - Stationary heater with remote control										V																							
C-CLASS	203		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	204		Drive	ME/CDI/CNG - Engine control unit			V	V																													
C-CLASS	204		Drive	ETC - Electronic transmission control						V	V	V																									
C-CLASS	204		Drive	ESM - Electronic selector module																																	
C-CLASS	204		Drive	SCR - Selective catalytic reduction																																	
C-CLASS	204		Drive	ISM - Intelligent servo module																																	
C-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
C-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	204		Drive	DTR - Distronic																																	
C-CLASS	204		Drive	AMG DRIVE UNIT																																	
C-CLASS	204		Drive	PTCU - Common powertrain controller																																	
C-CLASS	204		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	204		Chassis	Suspension											V																						
C-CLASS	204		Chassis	ES - Electrical power steering																																	
C-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	204		Body	WSS - Weight sensing system																																	
C-CLASS	204		Body	SCM [MRM] - Steering column module																																	
C-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
C-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	OCP - Overhead control panel																																	
C-CLASS	204		Body	Multifunction control unit																																	
C-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
C-CLASS	204		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
C-CLASS	204		Body	CGW - Central gateway																																	
C-CLASS	204		Body	AHE - Trailer recognition																																	
C-CLASS	204		Body	AB - Airbag																																	
C-CLASS	204		Information	Head-up display																																	
C-CLASS	204		Information	AVE-H - Rear audio video unit																																	
C-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
C-CLASS	204		Information	ZAN - Audio/COMAND display																																	
C-CLASS	204		Information	TV - TV tuner																																	
C-CLASS	204		Information	Sound generator for exhaust system																																	
C-CLASS	204		Information	SOUND - Sound system																																	
C-CLASS	204		Information	SGR - Radar sensors control unit																																	
C-CLASS	204		Information	360' - Camera																																	
C-CLASS	204		Information	MFK - Multifunction camera																																	
C-CLASS	204		Information	RFK - Backup camera																																	
C-CLASS	204		Information	PTS - Parktronic system																																	
C-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	204		Information	NBR-RF - Right front range radar																																	
C-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	204		Information	NBR-LF - Left front range radar																																	
C-CLASS	204		Information	NAV - Navigation module																																	
C-CLASS	204		Information	MIF/UCI - Media interface																																	
C-CLASS	204		Information	ICI - InCar Internet																																	
C-CLASS	204		Information	IC - Instrument cluster																																	
C-CLASS	204		Information	DVD player																																	
C-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
C-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
C-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
C-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	204		Information	AUDIO/COMAND																																	
C-CLASS	204		Information	AMG Performance Media																																	
C-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	204		Seat/Door	HKS - Tailgate control																																	
C-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
C-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
C-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																					V			V								V	
C-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																					V			V								V	
C-CLASS	204		Seat/Door	DCM-FR - Door control module front right																					V			V								V	
C-CLASS	204		Seat/Door	DCM-FL - Door control module front left																					V			V								V	
C-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	204		Air Conditioning	AAC - Automatic air conditioning																						V											
C-CLASS	205		Drive	SCR - Selective catalytic reduction																																	
C-CLASS	205		Drive	SG-EM - Power electronics																																	
C-CLASS	205		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	205		Drive	HFPM - Haptic accelerator pedal module																																	
C-CLASS	205		Drive	DTR - Distronic																																	
C-CLASS	205		Drive	ISM - Intelligent servo module																																	
C-CLASS	205		Drive	ME/CDI/CNG - Engine control unit				V																													
C-CLASS	205		Drive	ETC - Electronic transmission control																																	
C-CLASS	205		Drive	PTCU - Common powertrain controller																																	
C-CLASS	205		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	205		Chassis	Suspension																																	
C-CLASS	205		Chassis	ABS/ESP - Electronic stability program																		V															
C-CLASS	205		Chassis	ES - Electrical power steering																																	
C-CLASS	205		Chassis	EFB - Electric parking brake														V				V															
C-CLASS	205		Information	TPAD - Touchpad																																	
C-CLASS	205		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	205		Information	360' - Camera																																	
C-CLASS	205		Information	Sound generator for exhaust system																																	
C-CLASS	205		Information	SOUND - Sound system																																	
C-CLASS	205		Information	RFK - Backup camera																																	
C-CLASS	205		Information	SGR - Radar sensors control unit																																	
C-CLASS	205		Information	PTS - Parktronic system																																	
C-CLASS	205		Information	NBR-RF - Right front range radar																																	
C-CLASS	205		Information	NBR-LF - Left front range radar																																	
C-CLASS	205		Information	MFK - Multifunction camera																																	
C-CLASS	205		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	205		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	205		Information	Head-up display																																	
C-CLASS	205		Information	AUDIO/COMAND																																	
C-CLASS	205		Information	ZAN - Audio/COMAND display																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
C-CLASS	205		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	205		Information	KAB - Camera cover																																	
C-CLASS	205		Information	IC - Instrument cluster																																	
C-CLASS	205		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	205		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
C-CLASS	205		Body	AHE - Trailer recognition																																	
C-CLASS	205		Body	SCM [MRM] - Steering column module																																	
C-CLASS	205		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	RevETR-LF - Left front reversible emergency tensioning retractor												V																					
C-CLASS	205		Body	AB - Airbag																																	
C-CLASS	205		Body	Multifunction control unit																																	
C-CLASS	205		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
C-CLASS	205		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	205		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	205		Body	SG-AWF - Collision prevention assist																																	
C-CLASS	205		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	205		Body	BNS/BMS - Battery sensor																																	
C-CLASS	205		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	205		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	205		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
C-CLASS	205		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
C-CLASS	205		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	205		Seat/Door	HKS - Tailgate control																																	
C-CLASS	205		Seat/Door	DCM-RR - Door control module rear right																					V												
C-CLASS	205		Seat/Door	DCM-RL - Door control module rear left																					V												
C-CLASS	205		Seat/Door	DCM-FR - Door control module front right																					V												
C-CLASS	205		Seat/Door	DCM-FL - Door control module front left																					V												
C-CLASS	205		Seat/Door	RVC/VDS - Convertible roof control																																	
C-CLASS	205		Air Conditioning	AAC - Automatic air conditioning																						V											
E-CLASS	124		Drive	PMS/HFM/LH																																	
E-CLASS	124		Drive	ETC - Electronic transmission control																																	
E-CLASS	124		Drive	ISC - Idle speed control																																	
E-CLASS	124		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	124		Body	AB - Airbag																																	
E-CLASS	210		Drive	ME/CDI/CNG - Engine control unit																																	
E-CLASS	210		Drive	ETC - Electronic transmission control						V	V	V																									

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
E-CLASS	210		Drive	ESM - Electronic selector module																																	
E-CLASS	210		Chassis	ABS/ESP - Electronic stability program					V																												
E-CLASS	210		Chassis	VP - Vacuum pump brake booster																																	
E-CLASS	210		Chassis	PSE - Pneumatic system equipment																																	
E-CLASS	210		Chassis	BAS - Brake assist																																	
E-CLASS	210		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	210		Body	OCP - Overhead control panel																																	
E-CLASS	210		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	210		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	210		Body	AB - Airbag																																	
E-CLASS	210		Information	TV - TV tuner																																	
E-CLASS	210		Information	PTS - Parktronic system																																	
E-CLASS	210		Information	NAV - Navigation module																																	
E-CLASS	210		Information	IC - Instrument cluster																			V	V													
E-CLASS	210		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	210		Information	AUDIO/COMAND																																	
E-CLASS	210		Information	APS - Auto pilot system																																	
E-CLASS	210		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	210		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	210		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	210		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	210		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	210		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	210		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	210		Air Conditioning	HB - Heater booster																																	
E-CLASS	210		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	211		Drive	ME/CDI/CNG - Engine control unit			V	V																													
E-CLASS	211		Drive	ETC - Electronic transmission control						V	V	V																									
E-CLASS	211		Drive	ESM - Electronic selector module																																	
E-CLASS	211		Drive	Natural gas control unit																																	
E-CLASS	211		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	211		Drive	DTR - Distronic																V																	
E-CLASS	211		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	211		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	211		Chassis	Suspension																																	
E-CLASS	211		Chassis	SBC - Sensotronic Brake Control																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
E-CLASS	211		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	211		Body	WSS - Weight sensing system																																	
E-CLASS	211		Body	UCP - Upper control panel																																	
E-CLASS	211		Body	System diagnosis																																	
E-CLASS	211		Body	SCM [MRM] - Steering column module																																	
E-CLASS	211		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	211		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
E-CLASS	211		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																V																	
E-CLASS	211		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	OCP - Overhead control panel																																	
E-CLASS	211		Body	Multifunction control unit																																	
E-CLASS	211		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	211		Body	LAE [LAA] - Loading floor automatically extendable																																	
E-CLASS	211		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	211		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	211		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	211		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	211		Body	CGW - Central gateway																																	
E-CLASS	211		Body	BNS/BMS - Battery sensor																																	
E-CLASS	211		Body	AHE - Trailer recognition																																	
E-CLASS	211		Body	AB - Airbag																																	
E-CLASS	211		Information	TV - TV tuner																																	
E-CLASS	211		Information	SOUND - Sound system																																	
E-CLASS	211		Information	PTS - Parktronic system																																	
E-CLASS	211		Information	MIF/UCI - Media interface																																	
E-CLASS	211		Information	IC - Instrument cluster																				V													
E-CLASS	211		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	211		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	211		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	211		Information	AUDIO/COMAND																																	
E-CLASS	211		Information	ASSYST PLUS - PLUS Active Service System																																	
E-CLASS	211		Information	ASSYST Active Service System																				V													
E-CLASS	211		Information	AGW - Audio gateway																																	
E-CLASS	211		Seat/Door	REDC/RWT - Rear end door control module																																	V
E-CLASS	211		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
E-CLASS	211		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																		
E-CLASS	211		Seat/Door	ESA Driver - Electric seat adjustment Driver																																		
E-CLASS	211		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																		
E-CLASS	211		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																		
E-CLASS	211		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																		
E-CLASS	211		Seat/Door	DCM-RR - Door control module rear right																																		
E-CLASS	211		Seat/Door	DCM-RL - Door control module rear left																																		
E-CLASS	211		Seat/Door	DCM-FR - Door control module front right																																		
E-CLASS	211		Seat/Door	DCM-FL - Door control module front left																																		
E-CLASS	211		Air Conditioning	TSTH/STH - Stationary heater with remote control																																		
E-CLASS	211		Air Conditioning	AAC - Automatic air conditioning																																		
E-CLASS	207		Drive	SG-EM - Power electronics																																		
E-CLASS	207		Drive	SCR - Selective catalytic reduction																																		
E-CLASS	207		Drive	ME/CDI/CNG - Engine control unit			V	V																														
E-CLASS	207		Drive	ETC - Electronic transmission control						V	V	V																										
E-CLASS	207		Drive	ESM - Electronic selector module																																		
E-CLASS	207		Drive	ISM - Intelligent servo module																																		
E-CLASS	207		Drive	FSCU/FSCU-L - Control unit Fuel pump																																		
E-CLASS	207		Drive	DTR - Distronic																																		
E-CLASS	207		Drive	DSI - Direct select interface																																		
E-CLASS	207		Drive	AMG DRIVE UNIT																																		
E-CLASS	207		Chassis	ABS/ESP - Electronic stability program																																		
E-CLASS	207		Chassis	Suspension											V																							
E-CLASS	207		Chassis	ES - Electrical power steering																																		
E-CLASS	207		Chassis	FWGW - Chassis gateway																																		
E-CLASS	207		Chassis	TPM - Tire pressure monitor																																		
E-CLASS	207		Body	BNS/BMS - Battery sensor																																		
E-CLASS	207		Body	WSS - Weight sensing system																																		
E-CLASS	207		Body	SG-AWF - Collision prevention assist																																		
E-CLASS	207		Body	SCM [MRM] - Steering column module																																		
E-CLASS	207		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																		
E-CLASS	207		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																	
E-CLASS	207		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																		
E-CLASS	207		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																		
E-CLASS	207		Body	Multifunction control unit																																		
E-CLASS	207		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
E-CLASS	207		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
E-CLASS	207		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	207		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	207		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	207		Body	CGW - Central gateway																																	
E-CLASS	207		Body	AHE - Trailer recognition																																	
E-CLASS	207		Body	AB - Airbag																																	
E-CLASS	207		Information	NBR-RF - Right front range radar																																	
E-CLASS	207		Information	NBR-LF - Left front range radar																																	
E-CLASS	207		Information	AVE-H - Rear audio video unit																																	
E-CLASS	207		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	207		Information	ZAN - Audio/COMAND display																																	
E-CLASS	207		Information	TV - TV tuner																																	
E-CLASS	207		Information	SOUND - Sound system																																	
E-CLASS	207		Information	SGR - Radar sensors control unit																																	
E-CLASS	207		Information	360' - Camera																																	
E-CLASS	207		Information	MFK - Multifunction camera																																	
E-CLASS	207		Information	RFK - Backup camera																																	
E-CLASS	207		Information	PTS - Parktronic system																																	
E-CLASS	207		Information	NSA - Night View Assist																																	
E-CLASS	207		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	207		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	207		Information	NAV - Navigation module																																	
E-CLASS	207		Information	MIF/UCI - Media interface																																	
E-CLASS	207		Information	ICI - InCar Internet																																	
E-CLASS	207		Information	IC - Instrument cluster																																	
E-CLASS	207		Information	DVD player																																	
E-CLASS	207		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	207		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	207		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	207		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	207		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	207		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	207		Information	AUDIO/COMAND																																	
E-CLASS	207		Seat/Door	RVC/VDS - Convertible roof control																						V		V									
E-CLASS	207		Seat/Door	PSD/MSC - Sliding roof control																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
E-CLASS	207		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
E-CLASS	207		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
E-CLASS	207		Seat/Door	DCM-FR - Door control module front right																					V			V								V	
E-CLASS	207		Seat/Door	DCM-FL - Door control module front left																					V			V								V	
E-CLASS	207		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	207		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	207		Air Conditioning	AAC - Automatic air conditioning																						V											
E-CLASS	212		Drive	SG-EM - Power electronics																																	
E-CLASS	212		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	212		Drive	ME/CDI/CNG - Engine control unit			V	V																													
E-CLASS	212		Drive	ETC - Electronic transmission control						V	V	V																									
E-CLASS	212		Drive	ESM - Electronic selector module																																	
E-CLASS	212		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	212		Drive	ISM - Intelligent servo module																																	
E-CLASS	212		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	212		Drive	DTR - Distronic																																	
E-CLASS	212		Drive	DSI - Direct select interface																																	
E-CLASS	212		Drive	AMG DRIVE UNIT																																	
E-CLASS	212		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	212		Chassis	Suspension											V																						
E-CLASS	212		Chassis	ES - Electrical power steering																																	
E-CLASS	212		Chassis	FWGW - Chassis gateway																																	
E-CLASS	212		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	212		Body	BNS/BMS - Battery sensor																																	
E-CLASS	212		Body	WSS - Weight sensing system																																	
E-CLASS	212		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	212		Body	SCM [MRM] - Steering column module																																	
E-CLASS	212		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	212		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
E-CLASS	212		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	OCP - Overhead control panel																																	
E-CLASS	212		Body	Multifunction control unit																																	
E-CLASS	212		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
E-CLASS	212		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	212		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
E-CLASS	212		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	212		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	212		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	212		Body	CGW - Central gateway																																	
E-CLASS	212		Body	AHE - Trailer recognition																																	
E-CLASS	212		Body	AB - Airbag																																	
E-CLASS	212		Information	Head-up display																																	
E-CLASS	212		Information	AVE-H - Rear audio video unit																																	
E-CLASS	212		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	212		Information	ZAN - Audio/COMAND display																																	
E-CLASS	212		Information	TV - TV tuner																																	
E-CLASS	212		Information	SOUND - Sound system																																	
E-CLASS	212		Information	SGR - Radar sensors control unit																																	
E-CLASS	212		Information	360' - Camera																																	
E-CLASS	212		Information	MFK - Multifunction camera																																	
E-CLASS	212		Information	RFK - Backup camera																																	
E-CLASS	212		Information	PTS - Parktronic system																																	
E-CLASS	212		Information	NSA - Night View Assist																																	
E-CLASS	212		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	212		Information	NBR-RF - Right front range radar																																	
E-CLASS	212		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	212		Information	NBR-LF - Left front range radar																																	
E-CLASS	212		Information	NAV - Navigation module																																	
E-CLASS	212		Information	MIF/UCI - Media interface																																	
E-CLASS	212		Information	ICI - InCar Internet																																	
E-CLASS	212		Information	IC - Instrument cluster																																	
E-CLASS	212		Information	DVD player																																	
E-CLASS	212		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	212		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	212		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	212		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	212		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	212		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	212		Information	AUDIO/COMAND																																	
E-CLASS	212		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	212		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
E-CLASS	212		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
E-CLASS	212		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
E-CLASS	212		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	212		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DCM-RR - Door control module rear right																					V			V								V	
E-CLASS	212		Seat/Door	DCM-RL - Door control module rear left																					V			V								V	
E-CLASS	212		Seat/Door	DCM-FR - Door control module front right																					V			V								V	
E-CLASS	212		Seat/Door	DCM-FL - Door control module front left																					V			V								V	
E-CLASS	212		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	212		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	212		Air Conditioning	AAC - Automatic air conditioning																						V											
E-CLASS	213		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	213		Drive	DTR - Distronic																																	
E-CLASS	213		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	213		Drive	HFPM - Haptic accelerator pedal module																																	
E-CLASS	213		Drive	AMG DRIVE UNIT																																	
E-CLASS	213		Drive	PTCU - Common powertrain controller																																	
E-CLASS	213		Drive	ME/CDI/CNG - Engine control unit				V																													
E-CLASS	213		Drive	ETC - Electronic transmission control																																	
E-CLASS	213		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	213		Chassis	AIRMATIC PLUS																																	
E-CLASS	213		Chassis	ES - Electrical power steering																																	
E-CLASS	213		Chassis	Suspension																																	
E-CLASS	213		Chassis	ABS/ESP - Electronic stability program																		V															
E-CLASS	213		Body	MTAS - Mobile phone cradle																																	
E-CLASS	213		Body	AHE - Trailer recognition																																	
E-CLASS	213		Body	SCM [MRM] - Steering column module																																	
E-CLASS	213		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	RevETR-LF - Left front reversible emergency tensioning retractor											V																						
E-CLASS	213		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
E-CLASS	213		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
E-CLASS	213		Body	AB - Airbag																																	
E-CLASS	213		Body	OCP - Overhead control panel																																	
E-CLASS	213		Body	Multifunction control unit																																	
E-CLASS	213		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
E-CLASS	213		Body	SG-DDW - DC/DC converter control unit																																	
E-CLASS	213		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	213		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	213		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	213		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	213		Body	BNS/BMS - Battery sensor																																	
E-CLASS	213		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	213		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	213		Body	AML - Ambiance light																																	
E-CLASS	213		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
E-CLASS	213		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
E-CLASS	213		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
E-CLASS	213		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
E-CLASS	213		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	213		Seat/Door	HKS - Tailgate control																																	
E-CLASS	213		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	213		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DCM-RR - Door control module rear right																					V												
E-CLASS	213		Seat/Door	DCM-RL - Door control module rear left																					V												
E-CLASS	213		Seat/Door	DCM-FR - Door control module front right																					V												
E-CLASS	213		Seat/Door	DCM-FL - Door control module front left																					V												
E-CLASS	213		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	213		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	213		Information	TPAD - Touchpad																																	
E-CLASS	213		Information	Sound generator for exhaust system																																	
E-CLASS	213		Information	SOUND - Sound system																																	
E-CLASS	213		Information	RFK - Backup camera																																	
E-CLASS	213		Information	PTS - Parktronic system																																	
E-CLASS	213		Information	MFK - Multifunction camera																																	
E-CLASS	213		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	213		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	213		Information	SGR - Radar sensors control unit																																	
E-CLASS	213		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
E-CLASS	213		Information	Head-up display																																	
E-CLASS	213		Information	AUDIO/COMAND																																	
E-CLASS	213		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	213		Information	ZAN - Audio/COMAND display																																	
E-CLASS	213		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	213		Air Conditioning	AAC - Automatic air conditioning																					V												
S-CLASS	140		Drive	ASF																																	
S-CLASS	140		Drive	ERE																																	
S-CLASS	140		Drive	ME1LI																																	
S-CLASS	140		Drive	ME1RE																																	
S-CLASS	140		Drive	HFM/ME2/LH																																	
S-CLASS	140		Drive	ETC - Electronic transmission control																																	
S-CLASS	140		Drive	ISC - Idle speed control																																	
S-CLASS	140		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	140		Chassis	BAS - Brake assist																																	
S-CLASS	140		Body	PSE - Pneumatic system equipment																																	
S-CLASS	140		Body	AB - Airbag																																	
S-CLASS	140		Information	PTS - Parktronic system																																	
S-CLASS	140		Information	IC - Instrument cluster																																	
S-CLASS	140		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	220		Drive	ME/CDI/CNG - Engine control unit			V	V																													
S-CLASS	220		Drive	ETC - Electronic transmission control						V	V	V																									
S-CLASS	220		Drive	ESM - Electronic selector module																																	
S-CLASS	220		Drive	DTR - Distronic																																	
S-CLASS	220		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	220		Chassis	Suspension		V									V		V																				
S-CLASS	220		Chassis	PSE - Pneumatic system equipment																																	
S-CLASS	220		Chassis	ABS/ESP - Electronic stability program					V																												
S-CLASS	220		Body	UCP - Upper control panel																																	
S-CLASS	220		Body	System diagnosis																																	
S-CLASS	220		Body	SCM [MRM] - Steering column module																																	
S-CLASS	220		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	220		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
S-CLASS	220		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	220		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	220		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
S-CLASS	220		Body	OCP - Overhead control panel																																		
S-CLASS	220		Body	Multifunction control unit																																		
S-CLASS	220		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																		
S-CLASS	220		Body	HSW/LRH - Steering wheel heater																																		
S-CLASS	220		Body	Headlamp-R - Headlamp control unit																																		
S-CLASS	220		Body	Headlamp/Headlamp-L - Headlamp control unit																																		
S-CLASS	220		Body	EZS/EIS - Electronic ignition lock																																		
S-CLASS	220		Body	CGW - Central gateway																																		
S-CLASS	220		Body	AHE - Trailer recognition																																		
S-CLASS	220		Body	AB - Airbag																																		
S-CLASS	220		Information	TV - TV tuner																																		
S-CLASS	220		Information	PTS - Parktronic system																																		
S-CLASS	220		Information	NAV - Navigation module																																		
S-CLASS	220		Information	IC - Instrument cluster																			V	V														
S-CLASS	220		Information	DTA - Mbrace or TELEAID/GPS Box																																		
S-CLASS	220		Information	AUDIO/COMAND																																		
S-CLASS	220		Information	AGW - Audio gateway																																		
S-CLASS	220		Seat/Door	OSB-R - Multicontour backrest rear																																		
S-CLASS	220		Seat/Door	OSB-FL - Multicontour backrest front left																																		
S-CLASS	220		Seat/Door	ESA-R - Electric seat adjustment rear																																		
S-CLASS	220		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																										V	V	V	V	V	V		
S-CLASS	220		Seat/Door	ESA Driver - Electric seat adjustment Driver																										V	V	V	V	V	V		
S-CLASS	220		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																		
S-CLASS	220		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																		
S-CLASS	220		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																		
S-CLASS	220		Seat/Door	DCM-RR - Door control module rear right																																		
S-CLASS	220		Seat/Door	DCM-RL - Door control module rear left																																		
S-CLASS	220		Seat/Door	DCM-FR - Door control module front right																																		
S-CLASS	220		Seat/Door	DCM-FL - Door control module front left																																		
S-CLASS	220		Air Conditioning	TSTH/STH - Stationary heater with remote control																																		
S-CLASS	220		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																		
S-CLASS	220		Air Conditioning	AAC - Automatic air conditioning																																		
S-CLASS	221		Drive	ME/CDI/CNG - Engine control unit			V	V																														
S-CLASS	221		Drive	ETC - Electronic transmission control						V	V	V																										
S-CLASS	221		Drive	SCR - Selective catalytic reduction																																		
S-CLASS	221		Drive	ISM - Intelligent servo module																																		

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
S-CLASS	221		Drive	HSG - Hybrid control unit																		V															
S-CLASS	221		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	221		Drive	DTR - Distronic																V																	
S-CLASS	221		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	221		Chassis	Suspension																																	
S-CLASS	221		Chassis	ES - Electrical power steering																																	
S-CLASS	221		Chassis	EFB - Electric parking brake																																	
S-CLASS	221		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	221		Body	WSS - Weight sensing system																																	
S-CLASS	221		Body	UCP - Upper control panel																																	
S-CLASS	221		Body	System diagnosis																																	
S-CLASS	221		Body	SG-DDW - DC/DC converter control unit																																	
S-CLASS	221		Body	SCM [MRM] - Steering column module																																	
S-CLASS	221		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	221		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	221		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	OCP - Overhead control panel																																	
S-CLASS	221		Body	Multifunction control unit																																	
S-CLASS	221		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
S-CLASS	221		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	221		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	221		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	221		Body	CGW - Central gateway																																	
S-CLASS	221		Body	BNS/BMS - Battery sensor																																	
S-CLASS	221		Body	AHE - Trailer recognition																																	
S-CLASS	221		Body	AB - Airbag																																	
S-CLASS	221		Information	ZAN - Audio/COMAND display																																	
S-CLASS	221		Information	VCS - Voice control																																	
S-CLASS	221		Information	TV - TV tuner																																	
S-CLASS	221		Information	Tuner - Standard tuner																																	
S-CLASS	221		Information	SOUND - Sound system																																	
S-CLASS	221		Information	SGR - Radar sensors control unit																																	
S-CLASS	221		Information	MFK - Multifunction camera																																	
S-CLASS	221		Information	RFK - Backup camera																																	
S-CLASS	221		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
S-CLASS	221		Information	NSA - Night View Assist																																		
S-CLASS	221		Information	NBR-LF - Left front range radar																																		
S-CLASS	221		Information	NAV - Navigation module																																		
S-CLASS	221		Information	MIF/UCI - Media interface																																		
S-CLASS	221		Information	ICI - InCar Internet																																		
S-CLASS	221		Information	IC - Instrument cluster																																		
S-CLASS	221		Information	DVD player																																		
S-CLASS	221		Information	DTA - Mbrace or TELEAID/GPS Box																																		
S-CLASS	221		Information	D-FOR - Display in right rear passenger																																		
S-CLASS	221		Information	D-FOL - Display in left rear passenger																																		
S-CLASS	221		Information	DAB/SDAR - Digital/Satellite radio																																		
S-CLASS	221		Information	COU [ZBE] - Audio/COMAND operating unit																																		
S-CLASS	221		Information	AVE-H - Rear audio video unit																																		
S-CLASS	221		Information	AUDIO/COMAND																																		
S-CLASS	221		Information	ASSYST PLUS - PLUS Active Service System																																		
S-CLASS	221		Information	ASSYST Active Service System																																		
S-CLASS	221		Seat/Door	TSG-MR - Right center door control unit																																		
S-CLASS	221		Seat/Door	TSG-ML - Left center door control unit																																		
S-CLASS	221		Seat/Door	TLC/GTO - Garage door opener																																		
S-CLASS	221		Seat/Door	PSD/MSC - Sliding roof control																																		
S-CLASS	221		Seat/Door	MKL-HR - Rear right multicontour backrest																																		
S-CLASS	221		Seat/Door	MKL-HL - Rear left multicontour backrest																																		
S-CLASS	221		Seat/Door	HKS - Tailgate control																																		
S-CLASS	221		Seat/Door	ESA-R - Electric seat adjustment rear																																		
S-CLASS	221		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																		
S-CLASS	221		Seat/Door	ESA Driver - Electric seat adjustment Driver																																		
S-CLASS	221		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																		
S-CLASS	221		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																		
S-CLASS	221		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																		
S-CLASS	221		Seat/Door	DCM-RR - Door control module rear right																																		
S-CLASS	221		Seat/Door	DCM-RL - Door control module rear left																																		
S-CLASS	221		Seat/Door	DCM-FR - Door control module front right																																		
S-CLASS	221		Seat/Door	DCM-FL - Door control module front left																																		
S-CLASS	221		Air Conditioning	TSTH/STH - Stationary heater with remote control																																		
S-CLASS	221		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																		
S-CLASS	221		Air Conditioning	HBF - Rear control panel																																		

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
S-CLASS	221		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	217		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	217		Drive	SG-EM - Power electronics																																	
S-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	217		Drive	DTR - Distronic																																	
S-CLASS	217		Drive	ISM - Intelligent servo module																																	
S-CLASS	217		Drive	PTCU - Common powertrain controller																																	
S-CLASS	217		Drive	ME/CDI/CNG - Engine control unit				V																													
S-CLASS	217		Drive	ETC - Electronic transmission control																																	
S-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	217		Chassis	ABS/ESP - Electronic stability program																		V															
S-CLASS	217		Chassis	ES - Electrical power steering																																	
S-CLASS	217		Chassis	Suspension																																	
S-CLASS	217		Chassis	EFB - Electric parking brake														V				V															
S-CLASS	217		Information	TPAD - Touchpad																																	
S-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	217		Information	360' - Camera																																	
S-CLASS	217		Information	SOUND - Sound system																																	
S-CLASS	217		Information	RFK - Backup camera																																	
S-CLASS	217		Information	SGR - Radar sensors control unit																																	
S-CLASS	217		Information	PTS - Parktronic system																																	
S-CLASS	217		Information	NSA - Night View Assist																																	
S-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	217		Information	NBR-RF - Right front range radar																																	
S-CLASS	217		Information	NBR-LF - Left front range radar																																	
S-CLASS	217		Information	MFK - Multifunction camera																																	
S-CLASS	217		Information	Head-up display																																	
S-CLASS	217		Information	AUDIO/COMAND																																	
S-CLASS	217		Information	ZAN - Audio/COMAND display																																	
S-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	217		Information	KAB - Camera cover																																	
S-CLASS	217		Information	IC - Instrument cluster																																	
S-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	217		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
S-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor												V																					
S-CLASS	217		Body	AB - Airbag																																	
S-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
S-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	217		Body	BNS/BMS - Battery sensor																																	
S-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																				V													
S-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																				V													
S-CLASS	217		Seat/Door	HKS - Tailgate control																																	
S-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	217		Seat/Door	DCM-FR - Door control module front right																				V													
S-CLASS	217		Seat/Door	DCM-FL - Door control module front left																				V													
S-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
S-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																					V												
S-CLASS	222		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	222		Drive	SG-EM - Power electronics																																	
S-CLASS	222		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	222		Drive	DTR - Distronic																																	
S-CLASS	222		Drive	ISM - Intelligent servo module																																	
S-CLASS	222		Drive	PTCU - Common powertrain controller																																	
S-CLASS	222		Drive	ME/CDI/CNG - Engine control unit				V																													
S-CLASS	222		Drive	ETC - Electronic transmission control																																	
S-CLASS	222		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	222		Chassis	ES - Electrical power steering																																	
S-CLASS	222		Chassis	ABS/ESP - Electronic stability program																		V															
S-CLASS	222		Chassis	Suspension																																	
S-CLASS	222		Chassis	EFB - Electric parking brake														V				V															
S-CLASS	222		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
S-CLASS	222		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	222		Information	360' - Camera																																	
S-CLASS	222		Information	Sound generator for exhaust system																																	
S-CLASS	222		Information	SOUND - Sound system																																	
S-CLASS	222		Information	RFK - Backup camera																																	
S-CLASS	222		Information	SGR - Radar sensors control unit																																	
S-CLASS	222		Information	PTS - Parktronic system																																	
S-CLASS	222		Information	NSA - Night View Assist																																	
S-CLASS	222		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	222		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	222		Information	NBR-RF - Right front range radar																																	
S-CLASS	222		Information	NBR-LF - Left front range radar																																	
S-CLASS	222		Information	MFK - Multifunction camera																																	
S-CLASS	222		Information	Head-up display																																	
S-CLASS	222		Information	AUDIO/COMAND																																	
S-CLASS	222		Information	AVE-H - Rear audio video unit																																	
S-CLASS	222		Information	ZAN - Audio/COMAND display																																	
S-CLASS	222		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	222		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	222		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	222		Information	KAB - Camera cover																																	
S-CLASS	222		Information	IC - Instrument cluster																																	
S-CLASS	222		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	222		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	222		Body	AHE - Trailer recognition																																	
S-CLASS	222		Body	SCM [MRM] - Steering column module																																	
S-CLASS	222		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	RevETR-LF - Left front reversible emergency tensioning retractor												V																					
S-CLASS	222		Body	AB - Airbag																																	
S-CLASS	222		Body	Multifunction control unit																																	
S-CLASS	222		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
S-CLASS	222		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	222		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	222		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
S-CLASS	222		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	222		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
S-CLASS	222		Body	BNS/BMS - Battery sensor																																	
S-CLASS	222		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	222		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	222		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																				V													
S-CLASS	222		Seat/Door	ESA Driver - Electric seat adjustment Driver																				V													
S-CLASS	222		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
S-CLASS	222		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
S-CLASS	222		Seat/Door	HKS - Tailgate control																																	
S-CLASS	222		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	222		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	222		Seat/Door	DCM-RR - Door control module rear right																				V													
S-CLASS	222		Seat/Door	DCM-RL - Door control module rear left																				V													
S-CLASS	222		Seat/Door	DCM-FR - Door control module front right																				V													
S-CLASS	222		Seat/Door	DCM-FL - Door control module front left																				V													
S-CLASS	222		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	222		Air Conditioning	AAC - Automatic air conditioning																					V												
G-CLASS	461 - 38P Connector		Drive	EVE																																	
G-CLASS	461 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 38P Connector		Information	IC - Instrument cluster																																	
G-CLASS	461 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	461 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit				V																													
G-CLASS	461 - 16P Connector		Drive	ETC - Electronic transmission control						V	V	V																									
G-CLASS	461 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	461 - 16P Connector		Drive	VG - Transfer case									V																								
G-CLASS	461 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	461 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	461 - 16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
G-CLASS	461 - 16P Connector		Body	CGW - Central gateway																																	
G-CLASS	461 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 16P Connector		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
G-CLASS	461 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	461 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	461 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 38P Connector		Drive	ME/CDI/CNG - Engine control unit																																	
G-CLASS	463 - 38P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	463 - 38P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 38P Connector		Drive	CC - Cruise control																																	
G-CLASS	463 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	463 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 38P Connector		Information	IC - Instrument cluster																			V	V													
G-CLASS	463 - 38P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 38P Connector		Information	APS - Auto pilot system																																	
G-CLASS	463 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit			V	V																													
G-CLASS	463 - 16P Connector		Drive	ETC - Electronic transmission control						V	V	V																									
G-CLASS	463 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 16P Connector		Drive	VG - Transfer case									V																								
G-CLASS	463 - 16P Connector		Drive	SCR - Selective catalytic reduction																																	
G-CLASS	463 - 16P Connector		Drive	ISM - Intelligent servo module																																	
G-CLASS	463 - 16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
G-CLASS	463 - 16P Connector		Drive	DTR - Distronic																																	
G-CLASS	463 - 16P Connector		Drive	DSI - Direct select interface																																	
G-CLASS	463 - 16P Connector		Chassis	ABS/ESP - Electronic stability program					V																												
G-CLASS	463 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	463 - 16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
G-CLASS	463 - 16P Connector		Body	UCP - Upper control panel																																	
G-CLASS	463 - 16P Connector		Body	SCM [MRM] - Steering column module																																	
G-CLASS	463 - 16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
G-CLASS	463 - 16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																V	V																	
G-CLASS	463 - 16P Connector		Body	OCP - Overhead control panel																																	
G-CLASS	463 - 16P Connector		Body	Multifunction control unit																																	
G-CLASS	463 - 16P Connector		Body	HSW/LRH - Steering wheel heater																																	
G-CLASS	463 - 16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
G-CLASS	463 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	463 - 16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
G-CLASS	463 - 16P Connector		Body	AHE - Trailer recognition																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
G-CLASS	463 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 16P Connector		Information	ZAN - Audio/COMAND display																																	
G-CLASS	463 - 16P Connector		Information	TV - TV tuner																																	
G-CLASS	463 - 16P Connector		Information	SOUND - Sound system																																	
G-CLASS	463 - 16P Connector		Information	PTS - Parktronic system																																	
G-CLASS	463 - 16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NAV - Navigation module																																	
G-CLASS	463 - 16P Connector		Information	MIF/UCI - Media interface																																	
G-CLASS	463 - 16P Connector		Information	IC - Instrument cluster																				V													
G-CLASS	463 - 16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
G-CLASS	463 - 16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
G-CLASS	463 - 16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
G-CLASS	463 - 16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
G-CLASS	463 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	463 - 16P Connector		Seat/Door	HS - Seat heater																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
G-CLASS	463 - 16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RR - Door control module rear right																					V			V								V	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RL - Door control module rear left																					V			V								V	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FR - Door control module front right																V					V			V								V	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FL - Door control module front left																V					V			V								V	
G-CLASS	463 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control										V																							
G-CLASS	463 - 16P Connector		Air Conditioning	AAC - Automatic air conditioning																						V											
GLA-CLASS	156		Drive	VG - Transfer case																																	
GLA-CLASS	156		Drive	ME/CDI/CNG - Engine control unit				V																													
GLA-CLASS	156		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLA-CLASS	156		Drive	ETC - Electronic transmission control																																	
GLA-CLASS	156		Drive	DTR - Distronic																																	
GLA-CLASS	156		Drive	DSI - Direct select interface																																	
GLA-CLASS	156		Drive	PTCU - Common powertrain controller																																	
GLA-CLASS	156		Chassis	ABS/ESP - Electronic stability program																																	
GLA-CLASS	156		Chassis	ES - Electrical power steering																																	
GLA-CLASS	156		Chassis	EFB - Electric parking brake														V				V															
GLA-CLASS	156		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
GLA-CLASS	156		Body	SG-AWF - Collision prevention assist																																	
GLA-CLASS	156		Body	SCM [MRM] - Steering column module																																	
GLA-CLASS	156		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
GLA-CLASS	156		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	Multifunction control unit																																	
GLA-CLASS	156		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
GLA-CLASS	156		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLA-CLASS	156		Body	EZS/EIS - Electronic ignition lock																																	
GLA-CLASS	156		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLA-CLASS	156		Body	AHE - Trailer recognition																																	
GLA-CLASS	156		Body	AB - Airbag																																	
GLA-CLASS	156		Information	Head-up display																																	
GLA-CLASS	156		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLA-CLASS	156		Information	KAB - Camera cover																																	
GLA-CLASS	156		Information	ZAN - Audio/COMAND display																																	
GLA-CLASS	156		Information	TV - TV tuner																																	
GLA-CLASS	156		Information	SOUND - Sound system																																	
GLA-CLASS	156		Information	RFK - Backup camera																																	
GLA-CLASS	156		Information	MFK - Multifunction camera																																	
GLA-CLASS	156		Information	PTS - Parktronic system																																	
GLA-CLASS	156		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLA-CLASS	156		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLA-CLASS	156		Information	NAV - Navigation module																																	
GLA-CLASS	156		Information	MIF/UCI - Media interface																																	
GLA-CLASS	156		Information	IC - Instrument cluster																																	
GLA-CLASS	156		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLA-CLASS	156		Information	DAB/SDAR - Digital/Satellite radio																																	
GLA-CLASS	156		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLA-CLASS	156		Information	AUDIO/COMAND																																	
GLA-CLASS	156		Seat/Door	HKS - Tailgate control																																	
GLA-CLASS	156		Seat/Door	PSD/MSC - Sliding roof control																																	
GLA-CLASS	156		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
GLA-CLASS	156		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
GLA-CLASS	156		Seat/Door	DCM-FR - Door control module front right																					V			V								V	
GLA-CLASS	156		Seat/Door	DCM-FL - Door control module front left																					V			V								V	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
GLA-CLASS	156		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLA-CLASS	156		Air Conditioning	AAC - Automatic air conditioning																						V											
GLK-CLASS	204		Drive	ME/CDI/CNG - Engine control unit			V	V																													
GLK-CLASS	204		Drive	ETC - Electronic transmission control						V	V	V																									
GLK-CLASS	204		Drive	ESM - Electronic selector module																																	
GLK-CLASS	204		Drive	SCR - Selective catalytic reduction																																	
GLK-CLASS	204		Drive	PTCU - Common powertrain controller																																	
GLK-CLASS	204		Drive	ISM - Intelligent servo module																																	
GLK-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
GLK-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLK-CLASS	204		Drive	DTR - Distronic																																	
GLK-CLASS	204		Drive	AMG DRIVE UNIT																																	
GLK-CLASS	204		Chassis	ABS/ESP - Electronic stability program																																	
GLK-CLASS	204		Chassis	Suspension											V																						
GLK-CLASS	204		Chassis	ES - Electrical power steering																																	
GLK-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
GLK-CLASS	204		Body	WSS - Weight sensing system																																	
GLK-CLASS	204		Body	SCM [MRM] - Steering column module																																	
GLK-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLK-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
GLK-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	OCP - Overhead control panel																																	
GLK-CLASS	204		Body	Multifunction control unit																																	
GLK-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
GLK-CLASS	204		Body	Headlamp-R - Headlamp control unit																																	
GLK-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLK-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	
GLK-CLASS	204		Body	CGW - Central gateway																																	
GLK-CLASS	204		Body	AHE - Trailer recognition																																	
GLK-CLASS	204		Body	AB - Airbag																																	
GLK-CLASS	204		Information	Head-up display																																	
GLK-CLASS	204		Information	AVE-H - Rear audio video unit																																	
GLK-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLK-CLASS	204		Information	ZAN - Audio/COMAND display																																	
GLK-CLASS	204		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
GLK-CLASS	204		Information	Sound generator for exhaust system																																	
GLK-CLASS	204		Information	SOUND - Sound system																																	
GLK-CLASS	204		Information	SGR - Radar sensors control unit																																	
GLK-CLASS	204		Information	360' - Camera																																	
GLK-CLASS	204		Information	MFK - Multifunction camera																																	
GLK-CLASS	204		Information	RFK - Backup camera																																	
GLK-CLASS	204		Information	PTS - Parktronic system																																	
GLK-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLK-CLASS	204		Information	NBR-RF - Right front range radar																																	
GLK-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLK-CLASS	204		Information	NBR-LF - Left front range radar																																	
GLK-CLASS	204		Information	NAV - Navigation module																																	
GLK-CLASS	204		Information	MIF/UCI - Media interface																																	
GLK-CLASS	204		Information	ICI - InCar Internet																																	
GLK-CLASS	204		Information	IC - Instrument cluster																																	
GLK-CLASS	204		Information	DVD player																																	
GLK-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLK-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
GLK-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
GLK-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
GLK-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GLK-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLK-CLASS	204		Information	AUDIO/COMAND																																	
GLK-CLASS	204		Information	AMG Performance Media																																	
GLK-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
GLK-CLASS	204		Seat/Door	HKS - Tailgate control																																	
GLK-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																				V													
GLK-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																				V													
GLK-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																				V			V								V	
GLK-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																				V			V								V	
GLK-CLASS	204		Seat/Door	DCM-FR - Door control module front right																				V			V								V	
GLK-CLASS	204		Seat/Door	DCM-FL - Door control module front left																				V			V								V	
GLK-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLK-CLASS	204		Air Conditioning	AAC - Automatic air conditioning																					V												
GLC-CLASS	253		Drive	SCR - Selective catalytic reduction																																	
GLC-CLASS	253		Drive	SG-EM - Power electronics																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
GLC-CLASS	253		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLC-CLASS	253		Drive	DTR - Distronic																																	
GLC-CLASS	253		Drive	ISM - Intelligent servo module																																	
GLC-CLASS	253		Drive	PTCU - Common powertrain controller																																	
GLC-CLASS	253		Drive	ME/CDI/CNG - Engine control unit				V																													
GLC-CLASS	253		Drive	ETC - Electronic transmission control																																	
GLC-CLASS	253		Chassis	TPM - Tire pressure monitor																																	
GLC-CLASS	253		Chassis	AIRMATIC PLUS																																	
GLC-CLASS	253		Chassis	ES - Electrical power steering																																	
GLC-CLASS	253		Chassis	Suspension																																	
GLC-CLASS	253		Chassis	ABS/ESP - Electronic stability program																		V															
GLC-CLASS	253		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLC-CLASS	253		Body	AHE - Trailer recognition																																	
GLC-CLASS	253		Body	SCM [MRM] - Steering column module																																	
GLC-CLASS	253		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	RevETR-LF - Left front reversible emergency tensioning retractor												V																					
GLC-CLASS	253		Body	AB - Airbag																																	
GLC-CLASS	253		Body	Multifunction control unit																																	
GLC-CLASS	253		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
GLC-CLASS	253		Body	Headlamp-R - Headlamp control unit																																	
GLC-CLASS	253		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLC-CLASS	253		Body	SG-AWF - Collision prevention assist																																	
GLC-CLASS	253		Body	EZS/EIS - Electronic ignition lock																																	
GLC-CLASS	253		Body	BNS/BMS - Battery sensor																																	
GLC-CLASS	253		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLC-CLASS	253		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLC-CLASS	253		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																				V													
GLC-CLASS	253		Seat/Door	ESA Driver - Electric seat adjustment Driver																				V													
GLC-CLASS	253		Seat/Door	PSD/MSC - Sliding roof control																																	
GLC-CLASS	253		Seat/Door	HKS - Tailgate control																																	
GLC-CLASS	253		Seat/Door	DCM-RR - Door control module rear right																				V													
GLC-CLASS	253		Seat/Door	DCM-RL - Door control module rear left																				V													
GLC-CLASS	253		Seat/Door	DCM-FR - Door control module front right																				V													
GLC-CLASS	253		Seat/Door	DCM-FL - Door control module front left																				V													
GLC-CLASS	253		Information	TPAD - Touchpad																																	
GLC-CLASS	253		Information	DAB/SDAR - Digital/Satellite radio																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
GLC-CLASS	253		Information	360' - Camera																																	
GLC-CLASS	253		Information	Sound generator for exhaust system																																	
GLC-CLASS	253		Information	SOUND - Sound system																																	
GLC-CLASS	253		Information	RFK - Backup camera																																	
GLC-CLASS	253		Information	SGR - Radar sensors control unit																																	
GLC-CLASS	253		Information	PTS - Parktronic system																																	
GLC-CLASS	253		Information	NBR-RF - Right front range radar																																	
GLC-CLASS	253		Information	NBR-LF - Left front range radar																																	
GLC-CLASS	253		Information	MFK - Multifunction camera																																	
GLC-CLASS	253		Information	IC - Instrument cluster																																	
GLC-CLASS	253		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLC-CLASS	253		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLC-CLASS	253		Information	Head-up display																																	
GLC-CLASS	253		Information	AUDIO/COMAND																																	
GLC-CLASS	253		Information	SG-MSND - Engine sound																																	
GLC-CLASS	253		Information	ZAN - Audio/COMAND display																																	
GLC-CLASS	253		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLC-CLASS	253		Information	KAB - Camera cover																																	
GLC-CLASS	253		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLC-CLASS	253		Information	AMG Performance Media																																	
GLC-CLASS	253		Air Conditioning	AAC - Automatic air conditioning																					V												
GLE-CLASS	292		Drive	SCR - Selective catalytic reduction																																	
GLE-CLASS	292		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLE-CLASS	292		Drive	ISM - Intelligent servo module																																	
GLE-CLASS	292		Drive	DTR - Distronic																																	
GLE-CLASS	292		Drive	ME/CDI/CNG - Engine control unit				V																													
GLE-CLASS	292		Drive	ETC - Electronic transmission control																																	
GLE-CLASS	292		Chassis	TPM - Tire pressure monitor																																	
GLE-CLASS	292		Chassis	FWGW - Chassis gateway																																	
GLE-CLASS	292		Chassis	ABS/ESP - Electronic stability program																																	
GLE-CLASS	292		Chassis	ES - Electrical power steering																																	
GLE-CLASS	292		Chassis	EFB - Electric parking brake														V				V															
GLE-CLASS	292		Chassis	Suspension											V																						
GLE-CLASS	292		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLE-CLASS	292		Body	AHE - Trailer recognition																																	
GLE-CLASS	292		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
GLE-CLASS	292		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLE-CLASS	292		Body	AB - Airbag																																	
GLE-CLASS	292		Body	Multifunction control unit																																	
GLE-CLASS	292		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
GLE-CLASS	292		Body	Headlamp-R - Headlamp control unit																																	
GLE-CLASS	292		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLE-CLASS	292		Body	SG-AWF - Collision prevention assist																																	
GLE-CLASS	292		Body	EZS/EIS - Electronic ignition lock																																	
GLE-CLASS	292		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
GLE-CLASS	292		Information	TPAD - Touchpad																																	
GLE-CLASS	292		Information	DAB/SDAR - Digital/Satellite radio																																	
GLE-CLASS	292		Information	360' - Camera																																	
GLE-CLASS	292		Information	SOUND - Sound system																																	
GLE-CLASS	292		Information	RFK - Backup camera																																	
GLE-CLASS	292		Information	SGR - Radar sensors control unit																																	
GLE-CLASS	292		Information	PTS - Parktronic system																																	
GLE-CLASS	292		Information	MFK - Multifunction camera																																	
GLE-CLASS	292		Information	NBR-RF - Right front range radar																																	
GLE-CLASS	292		Information	NBR-LF - Left front range radar																																	
GLE-CLASS	292		Information	IC - Instrument cluster																																	
GLE-CLASS	292		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLE-CLASS	292		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLE-CLASS	292		Information	Head-up display																																	
GLE-CLASS	292		Information	AUDIO/COMAND																																	
GLE-CLASS	292		Information	AVE-H - Rear audio video unit																																	
GLE-CLASS	292		Information	DVD player																																	
GLE-CLASS	292		Information	SG-MSND - Engine sound																																	
GLE-CLASS	292		Information	ZAN - Audio/COMAND display																																	
GLE-CLASS	292		Information	D-FOR - Display in right rear passenger																																	
GLE-CLASS	292		Information	D-FOL - Display in left rear passenger																																	
GLE-CLASS	292		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLE-CLASS	292		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLE-CLASS	292		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
GLE-CLASS	292		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
GLE-CLASS	292		Seat/Door	PSD/MSC - Sliding roof control																																	
GLE-CLASS	292		Seat/Door	HKS - Tailgate control																																	
GLE-CLASS	292		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DCM-RR - Door control module rear right																					V		V									V	
GLE-CLASS	292		Seat/Door	DCM-RL - Door control module rear left																					V		V									V	
GLE-CLASS	292		Seat/Door	DCM-FR - Door control module front right																					V		V									V	
GLE-CLASS	292		Seat/Door	DCM-FL - Door control module front left																					V		V									V	
GLE-CLASS	292		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLE-CLASS	292		Air Conditioning	HBF - Rear control panel																																	
GLE-CLASS	292		Air Conditioning	AAC - Automatic air conditioning																						V											
GL-CLASS	164		Drive	ME/CDI/CNG - Engine control unit			V	V																													
GL-CLASS	164		Drive	ETC - Electronic transmission control																																	
GL-CLASS	164		Drive	VG - Transfer case																																	
GL-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
GL-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
GL-CLASS	164		Drive	SCR - Selective catalytic reduction																																	
GL-CLASS	164		Drive	ISM - Intelligent servo module																																	
GL-CLASS	164		Drive	HSG - Hybrid control unit																		V															
GL-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
GL-CLASS	164		Drive	DTR - Distronic																V																	
GL-CLASS	164		Chassis	ABS/ESP - Electronic stability program																																	
GL-CLASS	164		Chassis	Suspension																																	
GL-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
GL-CLASS	164		Chassis	ES - Electrical power steering																																	
GL-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	164		Body	WSS - Weight sensing system																																	
GL-CLASS	164		Body	UCP - Upper control panel																																	
GL-CLASS	164		Body	System diagnosis																																	
GL-CLASS	164		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																V																	
GL-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
GL-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
GL-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	164		Body	CGW - Central gateway																																	
GL-CLASS	164		Body	AB - Airbag																																	
GL-CLASS	164		Information	TV - TV tuner																																	
GL-CLASS	164		Information	SOUND - Sound system																																	
GL-CLASS	164		Information	RFK - Backup camera																																	
GL-CLASS	164		Information	PTS - Parktronic system																																	
GL-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	164		Information	NAV - Navigation module																																	
GL-CLASS	164		Information	MIF/UCI - Media interface																																	
GL-CLASS	164		Information	IC - Instrument cluster																				V													
GL-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GL-CLASS	164		Information	CM - Compass module																																	
GL-CLASS	164		Information	AVE-H - Rear audio video unit																																	
GL-CLASS	164		Information	AUDIO/COMAND																																	
GL-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
GL-CLASS	164		Information	ASSYST Active Service System																				V													
GL-CLASS	164		Information	AGW - Audio gateway																																	
GL-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	V
GL-CLASS	164		Seat/Door	HS - Seat heater																																	
GL-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
GL-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
GL-CLASS	164		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GL-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
GL-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
GL-CLASS	166		Drive	SG-EM - Power electronics																																	
GL-CLASS	166		Drive	PTCU - Common powertrain controller																																	
GL-CLASS	166		Drive	ME/CDI/CNG - Engine control unit				V																													
GL-CLASS	166		Drive	ETC - Electronic transmission control																																	
GL-CLASS	166		Drive	VG - Transfer case																																	
GL-CLASS	166		Drive	SCR - Selective catalytic reduction																																	
GL-CLASS	166		Drive	ISM - Intelligent servo module																																	
GL-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	166		Drive	DTR - Distronic																																	
GL-CLASS	166		Chassis	ABS/ESP - Electronic stability program																																	
GL-CLASS	166		Chassis	Suspension											V																						
GL-CLASS	166		Chassis	ES - Electrical power steering																																	
GL-CLASS	166		Chassis	EFB - Electric parking brake														V				V															
GL-CLASS	166		Chassis	FWGW - Chassis gateway																																	
GL-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
GL-CLASS	166		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
GL-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	Multifunction control unit																																	
GL-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
GL-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GL-CLASS	166		Body	AHE - Trailer recognition																																	
GL-CLASS	166		Body	AB - Airbag																																	
GL-CLASS	166		Information	Sound generator for exhaust system																																	
GL-CLASS	166		Information	Head-up display																																	
GL-CLASS	166		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
GL-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GL-CLASS	166		Information	ZAN - Audio/COMAND display																																	
GL-CLASS	166		Information	TV - TV tuner																																	
GL-CLASS	166		Information	SOUND - Sound system																																	
GL-CLASS	166		Information	SGR - Radar sensors control unit																																	
GL-CLASS	166		Information	360' - Camera																																	
GL-CLASS	166		Information	RFK - Backup camera																																	
GL-CLASS	166		Information	MFK - Multifunction camera																																	
GL-CLASS	166		Information	PTS - Parktronic system																																	
GL-CLASS	166		Information	NSA - Night View Assist																																	
GL-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	166		Information	NBR-RF - Right front range radar																																	
GL-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	166		Information	NBR-LF - Left front range radar																																	
GL-CLASS	166		Information	NAV - Navigation module																																	
GL-CLASS	166		Information	MIF/UCI - Media interface																																	
GL-CLASS	166		Information	IC - Instrument cluster																																	
GL-CLASS	166		Information	DVD player																																	
GL-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GL-CLASS	166		Information	AUDIO/COMAND																																	
GL-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
GL-CLASS	166		Seat/Door	HKS - Tailgate control																																	
GL-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																				V													
GL-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																				V													
GL-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																				V			V								V	
GL-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																				V			V								V	
GL-CLASS	166		Seat/Door	DCM-FR - Door control module front right																				V			V								V	
GL-CLASS	166		Seat/Door	DCM-FL - Door control module front left																				V			V								V	
GL-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
GL-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
GL-CLASS	166		Air Conditioning	AAC - Automatic air conditioning																						V											
M-CLASS	163		Drive	ME/CDI/CNG - Engine control unit																																	
M-CLASS	163		Drive	ETC - Electronic transmission control						V	V	V																									
M-CLASS	163		Drive	ESM - Electronic selector module																																	
M-CLASS	163		Drive	VG - Transfer case																																	
M-CLASS	163		Chassis	ABS/ESP - Electronic stability program					V																												
M-CLASS	163		Chassis	VP - Vacuum pump brake booster																																	
M-CLASS	163		Chassis	BAS - Brake assist																																	
M-CLASS	163		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	163		Body	AB - Airbag																																	
M-CLASS	163		Body	AAM - All activity module																																	
M-CLASS	163		Information	PTS - Parktronic system																																	
M-CLASS	163		Information	IC - Instrument cluster																			V														
M-CLASS	163		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	163		Information	AUDIO/COMAND																																	
M-CLASS	163		Air Conditioning	AAC - Automatic air conditioning															V																		
M-CLASS	163		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Drive	ME/CDI/CNG - Engine control unit			V	V																													
M-CLASS	164		Drive	ETC - Electronic transmission control																																	
M-CLASS	164		Drive	VG - Transfer case																																	
M-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
M-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
M-CLASS	164		Drive	SCR - Selective catalytic reduction																																	
M-CLASS	164		Drive	ISM - Intelligent servo module																																	
M-CLASS	164		Drive	HSG - Hybrid control unit																		V															
M-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
M-CLASS	164		Drive	DTR - Distronic																V																	
M-CLASS	164		Chassis	ABS/ESP - Electronic stability program																																	
M-CLASS	164		Chassis	Suspension																																	
M-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
M-CLASS	164		Chassis	ES - Electrical power steering																																	
M-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	164		Body	WSS - Weight sensing system																																	
M-CLASS	164		Body	UCP - Upper control panel																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
M-CLASS	164		Body	System diagnosis																																	
M-CLASS	164		Body	SCM [MRM] - Steering column module																																	
M-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side															V																		
M-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	OCP - Overhead control panel																																	
M-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
M-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	164		Body	CGW - Central gateway																																	
M-CLASS	164		Body	AB - Airbag																																	
M-CLASS	164		Information	TV - TV tuner																																	
M-CLASS	164		Information	SOUND - Sound system																																	
M-CLASS	164		Information	RFK - Backup camera																																	
M-CLASS	164		Information	PTS - Parktronic system																																	
M-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	164		Information	NAV - Navigation module																																	
M-CLASS	164		Information	MIF/UCI - Media interface																																	
M-CLASS	164		Information	IC - Instrument cluster																				V													
M-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
M-CLASS	164		Information	CM - Compass module																																	
M-CLASS	164		Information	AVE-H - Rear audio video unit																																	
M-CLASS	164		Information	AUDIO/COMAND																																	
M-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
M-CLASS	164		Information	ASSYST Active Service System																				V													
M-CLASS	164		Information	AGW - Audio gateway																																	
M-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	V
M-CLASS	164		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
M-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
M-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	164		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
M-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	166		Drive	SG-EM - Power electronics																																	
M-CLASS	166		Drive	ME/CDI/CNG - Engine control unit				V																													
M-CLASS	166		Drive	ETC - Electronic transmission control																																	
M-CLASS	166		Drive	VG - Transfer case																																	
M-CLASS	166		Drive	SCR - Selective catalytic reduction																																	
M-CLASS	166		Drive	PTCU - Common powertrain controller																																	
M-CLASS	166		Drive	ISM - Intelligent servo module																																	
M-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	166		Drive	DTR - Distronic																																	
M-CLASS	166		Chassis	ABS/ESP - Electronic stability program																																	
M-CLASS	166		Chassis	Suspension											V																						
M-CLASS	166		Chassis	ES - Electrical power steering																																	
M-CLASS	166		Chassis	EFB - Electric parking brake														V				V															
M-CLASS	166		Chassis	FWGW - Chassis gateway																																	
M-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
M-CLASS	166		Body	SCM [MRM] - Steering column module																																	
M-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
M-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	Multifunction control unit																																	
M-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
M-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
M-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
M-CLASS	166		Body	AHE - Trailer recognition																																	
M-CLASS	166		Body	AB - Airbag																																	
M-CLASS	166		Information	Sound generator for exhaust system																																	
M-CLASS	166		Information	Head-up display																																	
M-CLASS	166		Information	AVE-H - Rear audio video unit																																	
M-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
M-CLASS	166		Information	ZAN - Audio/COMAND display																																	
M-CLASS	166		Information	TV - TV tuner																																	
M-CLASS	166		Information	SOUND - Sound system																																	
M-CLASS	166		Information	SGR - Radar sensors control unit																																	
M-CLASS	166		Information	360' - Camera																																	
M-CLASS	166		Information	RFK - Backup camera																																	
M-CLASS	166		Information	MFK - Multifunction camera																																	
M-CLASS	166		Information	PTS - Parktronic system																																	
M-CLASS	166		Information	NSA - Night View Assist																																	
M-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	166		Information	NBR-RF - Right front range radar																																	
M-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	166		Information	NBR-LF - Left front range radar																																	
M-CLASS	166		Information	NAV - Navigation module																																	
M-CLASS	166		Information	MIF/UCI - Media interface																																	
M-CLASS	166		Information	IC - Instrument cluster																																	
M-CLASS	166		Information	DVD player																																	
M-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
M-CLASS	166		Information	AUDIO/COMAND																																	
M-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
M-CLASS	166		Seat/Door	HKS - Tailgate control																																	
M-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
M-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
M-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
M-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																					V			V								V	
M-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																					V			V								V	
M-CLASS	166		Seat/Door	DCM-FR - Door control module front right																					V			V								V	
M-CLASS	166		Seat/Door	DCM-FL - Door control module front left																					V			V								V	
M-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
M-CLASS	166		Air Conditioning	AAC - Automatic air conditioning																						V											
R-CLASS	251		Drive	ME/CDI/CNG - Engine control unit			V	V																													
R-CLASS	251		Drive	ETC - Electronic transmission control																																	
R-CLASS	251		Drive	SCR - Selective catalytic reduction																																	
R-CLASS	251		Drive	ISM - Intelligent servo module																																	
R-CLASS	251		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
R-CLASS	251		Drive	DTR - Distronic																V																	
R-CLASS	251		Chassis	ABS/ESP - Electronic stability program																																	
R-CLASS	251		Chassis	Suspension																																	
R-CLASS	251		Chassis	ES - Electrical power steering																																	
R-CLASS	251		Chassis	TPM - Tire pressure monitor																																	
R-CLASS	251		Body	WSS - Weight sensing system																																	
R-CLASS	251		Body	UCP - Upper control panel																																	
R-CLASS	251		Body	System diagnosis																																	
R-CLASS	251		Body	SCM [MRM] - Steering column module																																	
R-CLASS	251		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
R-CLASS	251		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																V																	
R-CLASS	251		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	OCP - Overhead control panel																																	
R-CLASS	251		Body	LCP/HBF - Lower/Rear control panel																																	
R-CLASS	251		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
R-CLASS	251		Body	Headlamp-R - Headlamp control unit																																	
R-CLASS	251		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
R-CLASS	251		Body	EZS/EIS - Electronic ignition lock																																	
R-CLASS	251		Body	CGW - Central gateway																																	
R-CLASS	251		Body	AB - Airbag																																	
R-CLASS	251		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
R-CLASS	251		Information	SOUND - Sound system																																	
R-CLASS	251		Information	RFK - Backup camera																																	
R-CLASS	251		Information	PTS - Parktronic system																																	
R-CLASS	251		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
R-CLASS	251		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
R-CLASS	251		Information	NAV - Navigation module																																	
R-CLASS	251		Information	MIF/UCI - Media interface																																	
R-CLASS	251		Information	IC - Instrument cluster																				V													
R-CLASS	251		Information	DTA - Mbrace or TELEAID/GPS Box																																	
R-CLASS	251		Information	D-FOR - Display in right rear passenger																																	
R-CLASS	251		Information	D-FOL - Display in left rear passenger																																	
R-CLASS	251		Information	DAB/SDAR - Digital/Satellite radio																																	
R-CLASS	251		Information	CTEL/TEL - Cellular/Mobile telephone																																	
R-CLASS	251		Information	CM - Compass module																																	
R-CLASS	251		Information	AVE-H - Rear audio video unit																																	
R-CLASS	251		Information	AUDIO/COMAND																																	
R-CLASS	251		Information	ASSYST PLUS - PLUS Active Service System																																	
R-CLASS	251		Information	ASSYST Active Service System																				V													
R-CLASS	251		Information	AGW - Audio gateway																																	
R-CLASS	251		Seat/Door	REDC/RWT - Rear end door control module																																	V
R-CLASS	251		Seat/Door	HS - Seat heater																																	
R-CLASS	251		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
R-CLASS	251		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
R-CLASS	251		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
R-CLASS	251		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DCM-FR - Door control module front right																																	
R-CLASS	251		Seat/Door	DCM-FL - Door control module front left																																	
R-CLASS	251		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
R-CLASS	251		Air Conditioning	AAC - Automatic air conditioning																																	
CLA-CLASS	117		Drive	VG - Transfer case																																	
CLA-CLASS	117		Drive	ME/CDI/CNG - Engine control unit				V																													
CLA-CLASS	117		Drive	ETC - Electronic transmission control																																	
CLA-CLASS	117		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLA-CLASS	117		Drive	DTR - Distronic																																	
CLA-CLASS	117		Drive	DSI - Direct select interface																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
CLA-CLASS	117		Drive	PTCU - Common powertrain controller																																	
CLA-CLASS	117		Chassis	ABS/ESP - Electronic stability program																																	
CLA-CLASS	117		Chassis	ES - Electrical power steering																																	
CLA-CLASS	117		Chassis	EFB - Electric parking brake														V				V															
CLA-CLASS	117		Chassis	TPM - Tire pressure monitor																																	
CLA-CLASS	117		Body	SG-AWF - Collision prevention assist																																	
CLA-CLASS	117		Body	SCM [MRM] - Steering column module																																	
CLA-CLASS	117		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
CLA-CLASS	117		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	Multifunction control unit																																	
CLA-CLASS	117		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
CLA-CLASS	117		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLA-CLASS	117		Body	EZS/EIS - Electronic ignition lock																																	
CLA-CLASS	117		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CLA-CLASS	117		Body	AHE - Trailer recognition																																	
CLA-CLASS	117		Body	AB - Airbag																																	
CLA-CLASS	117		Information	Head-up display																																	
CLA-CLASS	117		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLA-CLASS	117		Information	KAB - Camera cover																																	
CLA-CLASS	117		Information	ZAN - Audio/COMAND display																																	
CLA-CLASS	117		Information	TV - TV tuner																																	
CLA-CLASS	117		Information	SOUND - Sound system																																	
CLA-CLASS	117		Information	RFK - Backup camera																																	
CLA-CLASS	117		Information	MFK - Multifunction camera																																	
CLA-CLASS	117		Information	PTS - Parktronic system																																	
CLA-CLASS	117		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLA-CLASS	117		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLA-CLASS	117		Information	NAV - Navigation module																																	
CLA-CLASS	117		Information	MIF/UCI - Media interface																																	
CLA-CLASS	117		Information	IC - Instrument cluster																																	
CLA-CLASS	117		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLA-CLASS	117		Information	DAB/SDAR - Digital/Satellite radio																																	
CLA-CLASS	117		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLA-CLASS	117		Information	AUDIO/COMAND																																	
CLA-CLASS	117		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
CLA-CLASS	117		Seat/Door	PSD/MSC - Sliding roof control																																	
CLA-CLASS	117		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
CLA-CLASS	117		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
CLA-CLASS	117		Seat/Door	DCM-FR - Door control module front right																					V			V								V	
CLA-CLASS	117		Seat/Door	DCM-FL - Door control module front left																					V			V								V	
CLA-CLASS	117		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLA-CLASS	117		Air Conditioning	AAC - Automatic air conditioning																						V											
CLK-CLASS	208		Drive	ME/CDI/CNG - Engine control unit																																	
CLK-CLASS	208		Drive	ETC - Electronic transmission control						V	V	V																									
CLK-CLASS	208		Drive	ESM - Electronic selector module																																	
CLK-CLASS	208		Chassis	PSE - Pneumatic system equipment																																	
CLK-CLASS	208		Chassis	ABS/ESP - Electronic stability program					V																												
CLK-CLASS	208		Chassis	VP - Vacuum pump brake booster																																	
CLK-CLASS	208		Chassis	BAS - Brake assist																																	
CLK-CLASS	208		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	208		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	208		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	208		Body	OCP - Overhead control panel																																	
CLK-CLASS	208		Body	AB - Airbag																																	
CLK-CLASS	208		Information	TV - TV tuner																																	
CLK-CLASS	208		Information	PTS - Parktronic system																																	
CLK-CLASS	208		Information	NAV - Navigation module																																	
CLK-CLASS	208		Information	IC - Instrument cluster																			V	V													
CLK-CLASS	208		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	208		Information	AUDIO/COMAND																																	
CLK-CLASS	208		Information	APS - Auto pilot system																																	
CLK-CLASS	208		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	208		Air Conditioning	AAC - Automatic air conditioning																																	
CLK-CLASS	208		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	208		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	208		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	208		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Drive	ME/CDI/CNG - Engine control unit			V	V																													
CLK-CLASS	209		Drive	ETC - Electronic transmission control						V	V	V																									
CLK-CLASS	209		Drive	ESM - Electronic selector module																																	
CLK-CLASS	209		Drive	DTR - Distronic																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
CLK-CLASS	209		Chassis	ABS/ESP - Electronic stability program																																	
CLK-CLASS	209		Chassis	TPM - Tire pressure monitor																																	
CLK-CLASS	209		Body	WSS - Weight sensing system																																	
CLK-CLASS	209		Body	UCP - Upper control panel																																	
CLK-CLASS	209		Body	SCM [MRM] - Steering column module																																	
CLK-CLASS	209		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLK-CLASS	209		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																V																	
CLK-CLASS	209		Body	RCM - Rear control module																																	
CLK-CLASS	209		Body	OCP - Overhead control panel																																	
CLK-CLASS	209		Body	Multifunction control unit																																	
CLK-CLASS	209		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	209		Body	Headlamp-R - Headlamp control unit																																	
CLK-CLASS	209		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLK-CLASS	209		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	209		Body	BNS/BMS - Battery sensor																																	
CLK-CLASS	209		Body	AHE - Trailer recognition																																	
CLK-CLASS	209		Body	AB - Airbag																																	
CLK-CLASS	209		Information	TV - TV tuner																																	
CLK-CLASS	209		Information	PTS - Parktronic system																																	
CLK-CLASS	209		Information	NAV - Navigation module																																	
CLK-CLASS	209		Information	IC - Instrument cluster																				V													
CLK-CLASS	209		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	209		Information	AUDIO/COMAND																																	
CLK-CLASS	209		Information	AGW - Audio gateway																																	
CLK-CLASS	209		Seat/Door	RVC/VDS - Convertible roof control																																	
CLK-CLASS	209		Seat/Door	REDC/RWT - Rear end door control module																																	V
CLK-CLASS	209		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	209		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Seat/Door	DCM-FR - Door control module front right																V																	
CLK-CLASS	209		Seat/Door	DCM-FL - Door control module front left																V																	
CLK-CLASS	209		Air Conditioning	TSTH/STH - Stationary heater with remote control										V																							
CLK-CLASS	209		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	219		Drive	ME/CDI/CNG - Engine control unit			V	V																													
CLS-CLASS	219		Drive	ETC - Electronic transmission control						V	V	V																									
CLS-CLASS	219		Drive	ESM - Electronic selector module																																	
CLS-CLASS	219		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
CLS-CLASS	219		Drive	DTR - Distronic																V																	
CLS-CLASS	219		Chassis	ABS/ESP - Electronic stability program																																	
CLS-CLASS	219		Chassis	Suspension																																	
CLS-CLASS	219		Chassis	SBC - Sensotronic Brake Control																																	
CLS-CLASS	219		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	219		Body	WSS - Weight sensing system																																	
CLS-CLASS	219		Body	UCP - Upper control panel																																	
CLS-CLASS	219		Body	System diagnosis																																	
CLS-CLASS	219		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	219		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	219		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CLS-CLASS	219		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																V																	
CLS-CLASS	219		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	OCP - Overhead control panel																																	
CLS-CLASS	219		Body	LCP/HBF - Lower/Rear control panel																																	
CLS-CLASS	219		Body	LAE [LAA] - Loading floor automatically extendable																																	
CLS-CLASS	219		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	219		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	219		Body	CGW - Central gateway																																	
CLS-CLASS	219		Body	BNS/BMS - Battery sensor																																	
CLS-CLASS	219		Body	AB - Airbag																																	
CLS-CLASS	219		Information	TV - TV tuner																																	
CLS-CLASS	219		Information	SOUND - Sound system																																	
CLS-CLASS	219		Information	PTS - Parktronic system																																	
CLS-CLASS	219		Information	MIF/UCI - Media interface																																	
CLS-CLASS	219		Information	IC - Instrument cluster																				V													
CLS-CLASS	219		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	219		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	219		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	219		Information	AUDIO/COMAND																																	
CLS-CLASS	219		Information	ASSYST PLUS - PLUS Active Service System																																	
CLS-CLASS	219		Information	ASSYST Active Service System																				V													
CLS-CLASS	219		Information	AGW - Audio gateway																																	
CLS-CLASS	219		Seat/Door	REDC/RWT - Rear end door control module																																	V
CLS-CLASS	219		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
CLS-CLASS	219		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	219		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	219		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	219		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	219		Seat/Door	DCM-RL - Door control module rear left																																	
CLS-CLASS	219		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	219		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	219		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	219		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	218		Drive	ME/CDI/CNG - Engine control unit			V	V																													
CLS-CLASS	218		Drive	ETC - Electronic transmission control																																	
CLS-CLASS	218		Drive	ESM - Electronic selector module																																	
CLS-CLASS	218		Drive	SCR - Selective catalytic reduction																																	
CLS-CLASS	218		Drive	ISM - Intelligent servo module																																	
CLS-CLASS	218		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLS-CLASS	218		Drive	DTR - Distronic																																	
CLS-CLASS	218		Drive	DSI - Direct select interface																																	
CLS-CLASS	218		Drive	AMG DRIVE UNIT																																	
CLS-CLASS	218		Chassis	ABS/ESP - Electronic stability program																																	
CLS-CLASS	218		Chassis	Suspension											V																						
CLS-CLASS	218		Chassis	ES - Electrical power steering																																	
CLS-CLASS	218		Chassis	FWGW - Chassis gateway																																	
CLS-CLASS	218		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	218		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
CLS-CLASS	218		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
CLS-CLASS	218		Body	WSS - Weight sensing system																																	
CLS-CLASS	218		Body	SG-AWF - Collision prevention assist																																	
CLS-CLASS	218		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	218		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	218		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
CLS-CLASS	218		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	OCP - Overhead control panel																																	
CLS-CLASS	218		Body	Multifunction control unit																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
CLS-CLASS	218		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																	
CLS-CLASS	218		Body	HSW/LRH - Steering wheel heater																																		
CLS-CLASS	218		Body	HS/AIRSCARF - Seat heater/Air scarf system																																		
CLS-CLASS	218		Body	Headlamp-R - Headlamp control unit																																		
CLS-CLASS	218		Body	Headlamp/Headlamp-L - Headlamp control unit																																		
CLS-CLASS	218		Body	EZS/EIS - Electronic ignition lock																																		
CLS-CLASS	218		Body	CGW - Central gateway																																		
CLS-CLASS	218		Body	AHE - Trailer recognition																																		
CLS-CLASS	218		Body	AB - Airbag																																		
CLS-CLASS	218		Information	360' - Camera																																		
CLS-CLASS	218		Information	AVE-H - Rear audio video unit																																		
CLS-CLASS	218		Information	Drive Kit Plus - Drive kit for iPhone(R)																																		
CLS-CLASS	218		Information	ZAN - Audio/COMAND display																																		
CLS-CLASS	218		Information	TV - TV tuner																																		
CLS-CLASS	218		Information	SOUND - Sound system																																		
CLS-CLASS	218		Information	SGR - Radar sensors control unit																																		
CLS-CLASS	218		Information	MFK - Multifunction camera																																		
CLS-CLASS	218		Information	RFK - Backup camera																																		
CLS-CLASS	218		Information	PTS - Parktronic system																																		
CLS-CLASS	218		Information	NSA - Night View Assist																																		
CLS-CLASS	218		Information	NBR-RR/IRS-HRA - Right rear range radar																																		
CLS-CLASS	218		Information	NBR-RF - Right front range radar																																		
CLS-CLASS	218		Information	NBR-LR/IRS-HLA - Left rear range radar																																		
CLS-CLASS	218		Information	NBR-LF - Left front range radar																																		
CLS-CLASS	218		Information	NAV - Navigation module																																		
CLS-CLASS	218		Information	MIF/UCI - Media interface																																		
CLS-CLASS	218		Information	ICI - InCar Internet																																		
CLS-CLASS	218		Information	IC - Instrument cluster																																		
CLS-CLASS	218		Information	DVD player																																		
CLS-CLASS	218		Information	DTA - Mbrace or TELEAID/GPS Box																																		
CLS-CLASS	218		Information	D-FOR - Display in right rear passenger																																		
CLS-CLASS	218		Information	D-FOL - Display in left rear passenger																																		
CLS-CLASS	218		Information	DAB/SDAR - Digital/Satellite radio																																		
CLS-CLASS	218		Information	CTEL/TEL - Cellular/Mobile telephone																																		
CLS-CLASS	218		Information	COU [ZBE] - Audio/COMAND operating unit																																		
CLS-CLASS	218		Information	AUDIO/COMAND																																		

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
CLS-CLASS	218		Seat/Door	PSD/MSC - Sliding roof control																																	
CLS-CLASS	218		Seat/Door	HKS - Tailgate control																																	
CLS-CLASS	218		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
CLS-CLASS	218		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
CLS-CLASS	218		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	218		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DCM-RR - Door control module rear right																					V			V								V	
CLS-CLASS	218		Seat/Door	DCM-RL - Door control module rear left																					V			V								V	
CLS-CLASS	218		Seat/Door	DCM-FR - Door control module front right																					V			V								V	
CLS-CLASS	218		Seat/Door	DCM-FL - Door control module front left																					V			V								V	
CLS-CLASS	218		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	218		Air Conditioning	AAC - Automatic air conditioning																						V											
CL-CLASS	215		Drive	ME/CDI/CNG - Engine control unit																																	
CL-CLASS	215		Drive	ETC - Electronic transmission control						V	V	V																									
CL-CLASS	215		Drive	ESM - Electronic selector module																																	
CL-CLASS	215		Drive	DTR - Distronic																																	
CL-CLASS	215		Chassis	ABS/ESP - Electronic stability program					V																												
CL-CLASS	215		Chassis	Suspension		V									V		V																				
CL-CLASS	215		Chassis	PSE - Pneumatic system equipment																																	
CL-CLASS	215		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	215		Body	UCP - Upper control panel																																	
CL-CLASS	215		Body	System diagnosis																																	
CL-CLASS	215		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	215		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	215		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CL-CLASS	215		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	215		Body	RCM - Rear control module																																	
CL-CLASS	215		Body	OCP - Overhead control panel																																	
CL-CLASS	215		Body	Multifunction control unit																																	
CL-CLASS	215		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	215		Body	HSW/LRH - Steering wheel heater																																	
CL-CLASS	215		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	215		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	215		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	215		Body	CGW - Central gateway																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
CL-CLASS	215		Body	AHE - Trailer recognition																																	
CL-CLASS	215		Body	AB - Airbag																																	
CL-CLASS	215		Information	TV - TV tuner																																	
CL-CLASS	215		Information	PTS - Parktronic system																																	
CL-CLASS	215		Information	NAV - Navigation module																																	
CL-CLASS	215		Information	IC - Instrument cluster																			V	V													
CL-CLASS	215		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	215		Information	AUDIO/COMAND																																	
CL-CLASS	215		Information	AGW - Audio gateway																																	
CL-CLASS	215		Seat/Door	OSB-FR - Multicontour backrest front right																																	
CL-CLASS	215		Seat/Door	OSB-FL - Multicontour backrest front left																																	
CL-CLASS	215		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																									V	V	V	V	V	V		
CL-CLASS	215		Seat/Door	ESA Driver - Electric seat adjustment Driver																									V	V	V	V	V	V		
CL-CLASS	215		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	215		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	215		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	215		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
CL-CLASS	215		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	216		Drive	ME/CDI/CNG - Engine control unit			V	V																													
CL-CLASS	216		Drive	ETC - Electronic transmission control						V	V	V																									
CL-CLASS	216		Drive	ISM - Intelligent servo module																																	
CL-CLASS	216		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	216		Drive	DTR - Distronic																V																	
CL-CLASS	216		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	216		Chassis	Suspension																																	
CL-CLASS	216		Chassis	ES - Electrical power steering																																	
CL-CLASS	216		Chassis	EFB - Electric parking brake																																	
CL-CLASS	216		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	216		Body	WSS - Weight sensing system																																	
CL-CLASS	216		Body	UCP - Upper control panel																																	
CL-CLASS	216		Body	System diagnosis																																	
CL-CLASS	216		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	216		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	216		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	216		Body	RCM - Rear control module																																	
CL-CLASS	216		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
CL-CLASS	216		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																	
CL-CLASS	216		Body	Headlamp-R - Headlamp control unit																																		
CL-CLASS	216		Body	Headlamp/Headlamp-L - Headlamp control unit																																		
CL-CLASS	216		Body	EZS/EIS - Electronic ignition lock																																		
CL-CLASS	216		Body	CGW - Central gateway																																		
CL-CLASS	216		Body	BNS/BMS - Battery sensor																																		
CL-CLASS	216		Body	AHE - Trailer recognition																																		
CL-CLASS	216		Body	AB - Airbag																																		
CL-CLASS	216		Information	ZAN - Audio/COMAND display																																		
CL-CLASS	216		Information	VCS - Voice control																																		
CL-CLASS	216		Information	TV - TV tuner																																		
CL-CLASS	216		Information	Tuner - Standard tuner																																		
CL-CLASS	216		Information	SGR - Radar sensors control unit																																		
CL-CLASS	216		Information	MFK - Multifunction camera																																		
CL-CLASS	216		Information	RFK - Backup camera																																		
CL-CLASS	216		Information	PTS - Parktronic system																																		
CL-CLASS	216		Information	NSA - Night View Assist																																		
CL-CLASS	216		Information	NBR-LF - Left front range radar																																		
CL-CLASS	216		Information	NAV - Navigation module																																		
CL-CLASS	216		Information	MIF/UCI - Media interface																																		
CL-CLASS	216		Information	ICI - InCar Internet																																		
CL-CLASS	216		Information	IC - Instrument cluster																																		
CL-CLASS	216		Information	DTA - Mbrace or TELEAID/GPS Box																																		
CL-CLASS	216		Information	DAB/SDAR - Digital/Satellite radio																																		
CL-CLASS	216		Information	COU [ZBE] - Audio/COMAND operating unit																																		
CL-CLASS	216		Information	AUDIO/COMAND																																		
CL-CLASS	216		Information	ASSYST PLUS - PLUS Active Service System																																		
CL-CLASS	216		Information	ASSYST Active Service System																																		
CL-CLASS	216		Seat/Door	TLC/GTO - Garage door opener																																		
CL-CLASS	216		Seat/Door	HKS - Tailgate control																																		
CL-CLASS	216		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																		
CL-CLASS	216		Seat/Door	ESA Driver - Electric seat adjustment Driver																																		
CL-CLASS	216		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																		
CL-CLASS	216		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																		
CL-CLASS	216		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																		
CL-CLASS	216		Seat/Door	DCM-FR - Door control module front right																																		

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
CL-CLASS	216		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	216		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	216		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	217		Drive	SCR - Selective catalytic reduction																																	
CL-CLASS	217		Drive	SG-EM - Power electronics																																	
CL-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	217		Drive	DTR - Distronic																																	
CL-CLASS	217		Drive	ISM - Intelligent servo module																																	
CL-CLASS	217		Drive	ME/CDI/CNG - Engine control unit				V																													
CL-CLASS	217		Drive	ETC - Electronic transmission control																																	
CL-CLASS	217		Drive	PTCU - Common powertrain controller																																	
CL-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	217		Chassis	ABS/ESP - Electronic stability program																		V															
CL-CLASS	217		Chassis	ES - Electrical power steering																																	
CL-CLASS	217		Chassis	Suspension																																	
CL-CLASS	217		Chassis	EFB - Electric parking brake														V				V															
CL-CLASS	217		Information	TPAD - Touchpad																																	
CL-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	217		Information	360' - Camera																																	
CL-CLASS	217		Information	SOUND - Sound system																																	
CL-CLASS	217		Information	RFK - Backup camera																																	
CL-CLASS	217		Information	SGR - Radar sensors control unit																																	
CL-CLASS	217		Information	PTS - Parktronic system																																	
CL-CLASS	217		Information	NSA - Night View Assist																																	
CL-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CL-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CL-CLASS	217		Information	NBR-RF - Right front range radar																																	
CL-CLASS	217		Information	NBR-LF - Left front range radar																																	
CL-CLASS	217		Information	MFK - Multifunction camera																																	
CL-CLASS	217		Information	Head-up display																																	
CL-CLASS	217		Information	AUDIO/COMAND																																	
CL-CLASS	217		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	217		Information	KAB - Camera cover																																	
CL-CLASS	217		Information	IC - Instrument cluster																																	
CL-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
CL-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CL-CLASS	217		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor												V																					
CL-CLASS	217		Body	AB - Airbag																																	
CL-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
CL-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
CL-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	217		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																				V													
CL-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																				V													
CL-CLASS	217		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
CL-CLASS	217		Seat/Door	DCM-FR - Door control module front right																				V													
CL-CLASS	217		Seat/Door	DCM-FL - Door control module front left																				V													
CL-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
CL-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																					V												
SLK-CLASS	170		Drive	ME/CDI/CNG - Engine control unit																																	
SLK-CLASS	170		Drive	ETC - Electronic transmission control						V	V	V																									
SLK-CLASS	170		Drive	ESM - Electronic selector module																																	
SLK-CLASS	170		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	170		Chassis	VP - Vacuum pump brake booster																																	
SLK-CLASS	170		Chassis	BAS - Brake assist																																	
SLK-CLASS	170		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	170		Body	AB - Airbag																																	
SLK-CLASS	170		Information	IC - Instrument cluster																			V														
SLK-CLASS	170		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	170		Information	AUDIO/COMAND																																	
SLK-CLASS	170		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
SLK-CLASS	170		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	171		Drive	ME/CDI/CNG - Engine control unit			V	V																													
SLK-CLASS	171		Drive	ETC - Electronic transmission control						V	V	V																									
SLK-CLASS	171		Drive	ESM - Electronic selector module																																	
SLK-CLASS	171		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	171		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	171		Body	WSS - Weight sensing system																																	
SLK-CLASS	171		Body	UCP - Upper control panel																																	
SLK-CLASS	171		Body	System diagnosis																																	
SLK-CLASS	171		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	171		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	171		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																V																	
SLK-CLASS	171		Body	OCP - Overhead control panel																																	
SLK-CLASS	171		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	171		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	171		Body	CGW - Central gateway																																	
SLK-CLASS	171		Body	AB - Airbag																																	
SLK-CLASS	171		Information	TV - TV tuner																																	
SLK-CLASS	171		Information	SOUND - Sound system																																	
SLK-CLASS	171		Information	PTS - Parktronic system																																	
SLK-CLASS	171		Information	MIF/UCI - Media interface																																	
SLK-CLASS	171		Information	IC - Instrument cluster																				V													
SLK-CLASS	171		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	171		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	171		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SLK-CLASS	171		Information	AUDIO/COMAND																																	
SLK-CLASS	171		Information	ASSYST PLUS - PLUS Active Service System																																	
SLK-CLASS	171		Information	ASSYST Active Service System																				V													
SLK-CLASS	171		Information	AGW - Audio gateway																																	
SLK-CLASS	171		Seat/Door	RVC/VDS - Convertible roof control																																	
SLK-CLASS	171		Seat/Door	HS - Seat heater																																	
SLK-CLASS	171		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	171		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	171		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	171		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	171		Air Conditioning	AAC - Automatic air conditioning																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
SLK-CLASS	172		Drive	ME/CDI/CNG - Engine control unit				V																													
SLK-CLASS	172		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	172		Drive	ESM - Electronic selector module																																	
SLK-CLASS	172		Drive	DTR - Distronic																																	
SLK-CLASS	172		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLK-CLASS	172		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	172		Chassis	Suspension											V																						
SLK-CLASS	172		Chassis	ES - Electrical power steering																																	
SLK-CLASS	172		Chassis	EFB - Electric parking brake														V				V															
SLK-CLASS	172		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	172		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	172		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	172		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
SLK-CLASS	172		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
SLK-CLASS	172		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLK-CLASS	172		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	172		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	172		Body	CGW - Central gateway																																	
SLK-CLASS	172		Body	AB - Airbag																																	
SLK-CLASS	172		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SLK-CLASS	172		Information	ZAN - Audio/COMAND display																																	
SLK-CLASS	172		Information	TV - TV tuner																																	
SLK-CLASS	172		Information	SOUND - Sound system																																	
SLK-CLASS	172		Information	SGR - Radar sensors control unit																																	
SLK-CLASS	172		Information	MFK - Multifunction camera																																	
SLK-CLASS	172		Information	PTS - Parktronic system																																	
SLK-CLASS	172		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLK-CLASS	172		Information	NBR-RF - Right front range radar																																	
SLK-CLASS	172		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLK-CLASS	172		Information	NBR-LF - Left front range radar																																	
SLK-CLASS	172		Information	NAV - Navigation module																																	
SLK-CLASS	172		Information	MIF/UCI - Media interface																																	
SLK-CLASS	172		Information	IC - Instrument cluster																																	
SLK-CLASS	172		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
SLK-CLASS	172		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	172		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLK-CLASS	172		Information	AUDIO/COMAND																																	
SLK-CLASS	172		Seat/Door	RVC/VDS - Convertible roof control																						V		V									
SLK-CLASS	172		Seat/Door	PSD/MSC - Sliding roof control																																	
SLK-CLASS	172		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
SLK-CLASS	172		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
SLK-CLASS	172		Seat/Door	DCM-FR - Door control module front right																					V			V								V	
SLK-CLASS	172		Seat/Door	DCM-FL - Door control module front left																					V			V								V	
SLK-CLASS	172		Air Conditioning	AAC - Automatic air conditioning																						V											
SL-CLASS	129		Drive	ME/CDI/CNG - Engine control unit																																	
SL-CLASS	129		Drive	ETC - Electronic transmission control																																	
SL-CLASS	129		Chassis	ABS/ESP - Electronic stability program					V																												
SL-CLASS	129		Chassis	BAS - Brake assist																																	
SL-CLASS	129		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	129		Body	AB - Airbag																																	
SL-CLASS	129		Information	NAV - Navigation module																																	
SL-CLASS	129		Information	IC - Instrument cluster																			V	V													
SL-CLASS	129		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	129		Information	AUDIO/COMAND																																	
SL-CLASS	129		Information	APS - Auto pilot system																																	
SL-CLASS	129		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	129		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	230		Drive	ME/CDI/CNG - Engine control unit			V	V																													
SL-CLASS	230		Drive	ETC - Electronic transmission control						V	V	V																									
SL-CLASS	230		Drive	ESM - Electronic selector module																																	
SL-CLASS	230		Drive	DTR - Distronic																V																	
SL-CLASS	230		Drive	AMG DRIVE UNIT																																	
SL-CLASS	230		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	230		Chassis	Suspension		V									V		V																				
SL-CLASS	230		Chassis	SBC - Sensotronic Brake Control																																	
SL-CLASS	230		Chassis	PSE - Pneumatic system equipment																																	
SL-CLASS	230		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	230		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	230		Body	WSS - Weight sensing system																																	
SL-CLASS	230		Body	System diagnosis																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
SL-CLASS	230		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	230		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	230		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SL-CLASS	230		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	230		Body	OCP - Overhead control panel																																	
SL-CLASS	230		Body	LCP/HBF - Lower/Rear control panel																																	
SL-CLASS	230		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	230		Body	HSW/LRH - Steering wheel heater																																	
SL-CLASS	230		Body	Headlamp-R - Headlamp control unit																																	
SL-CLASS	230		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	230		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	230		Body	CGW - Central gateway																																	
SL-CLASS	230		Body	BNS/BMS - Battery sensor																																	
SL-CLASS	230		Body	AB - Airbag																																	
SL-CLASS	230		Information	TV - TV tuner																																	
SL-CLASS	230		Information	SOUND - Sound system																																	
SL-CLASS	230		Information	PTS - Parktronic system																																	
SL-CLASS	230		Information	MIF/UCI - Media interface																																	
SL-CLASS	230		Information	IC - Instrument cluster																				V													
SL-CLASS	230		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	230		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	230		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SL-CLASS	230		Information	AUDIO/COMAND																																	
SL-CLASS	230		Information	AGW - Audio gateway																																	
SL-CLASS	230		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	230		Seat/Door	OSB-FR - Multicontour backrest front right																																	
SL-CLASS	230		Seat/Door	OSB-FL - Multicontour backrest front left																																	
SL-CLASS	230		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																									V	V	V	V	V	V			
SL-CLASS	230		Seat/Door	ESA Driver - Electric seat adjustment Driver																									V	V	V	V	V	V			
SL-CLASS	230		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	230		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	230		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	230		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	231		Drive	ME/CDI/CNG - Engine control unit				V																													
SL-CLASS	231		Drive	ETC - Electronic transmission control																																	
SL-CLASS	231		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
SL-CLASS	231		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SL-CLASS	231		Drive	DTR - Distronic																																	
SL-CLASS	231		Drive	DSI - Direct select interface																																	
SL-CLASS	231		Drive	AMG DRIVE UNIT																																	
SL-CLASS	231		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	231		Chassis	Suspension											V																						
SL-CLASS	231		Chassis	ES - Electrical power steering																																	
SL-CLASS	231		Chassis	EFB - Electric parking brake														V				V															
SL-CLASS	231		Chassis	FWGW - Chassis gateway																																	
SL-CLASS	231		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	231		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	231		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	231		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
SL-CLASS	231		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
SL-CLASS	231		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	231		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	231		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	231		Body	CGW - Central gateway																																	
SL-CLASS	231		Body	AB - Airbag																																	
SL-CLASS	231		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SL-CLASS	231		Information	ZAN - Audio/COMAND display																																	
SL-CLASS	231		Information	TV - TV tuner																																	
SL-CLASS	231		Information	SOUND - Sound system																																	
SL-CLASS	231		Information	SGR - Radar sensors control unit																																	
SL-CLASS	231		Information	RFK - Backup camera																																	
SL-CLASS	231		Information	MFK - Multifunction camera																																	
SL-CLASS	231		Information	PTS - Parktronic system																																	
SL-CLASS	231		Information	NSA - Night View Assist																																	
SL-CLASS	231		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SL-CLASS	231		Information	NBR-RF - Right front range radar																																	
SL-CLASS	231		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SL-CLASS	231		Information	NBR-LF - Left front range radar																																	
SL-CLASS	231		Information	MIF/UCI - Media interface																																	
SL-CLASS	231		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
SL-CLASS	231		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	231		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	231		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SL-CLASS	231		Information	AUDIO/COMAND																																	
SL-CLASS	231		Information	AMG Performance Media																																	
SL-CLASS	231		Seat/Door	RVC/VDS - Convertible roof control																						V		V									
SL-CLASS	231		Seat/Door	PSD/MSC - Sliding roof control																																	
SL-CLASS	231		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V												
SL-CLASS	231		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V												
SL-CLASS	231		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
SL-CLASS	231		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DCM-FR - Door control module front right																					V			V								V	
SL-CLASS	231		Seat/Door	DCM-FL - Door control module front left																					V			V								V	
SL-CLASS	231		Air Conditioning	AAC - Automatic air conditioning																						V											
SLS-CLASS	197		Drive	PTCU - Common powertrain controller																																	
SLS-CLASS	197		Drive	ME/CDI/CNG - Engine control unit			V	V																													
SLS-CLASS	197		Drive	ETC - Electronic transmission control																																	
SLS-CLASS	197		Drive	ISM - Intelligent servo module																																	
SLS-CLASS	197		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLS-CLASS	197		Drive	DSI - Direct select interface																																	
SLS-CLASS	197		Drive	AMG DRIVE UNIT																																	
SLS-CLASS	197		Chassis	ABS/ESP - Electronic stability program																																	
SLS-CLASS	197		Chassis	Suspension											V																						
SLS-CLASS	197		Chassis	ES - Electrical power steering																																	
SLS-CLASS	197		Chassis	EFB - Electric parking brake														V				V															
SLS-CLASS	197		Chassis	TPM - Tire pressure monitor																																	
SLS-CLASS	197		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	CSHV - Crash sensor/high-voltage battery																																	
SLS-CLASS	197		Body	BNS/BMS - Battery sensor				V																													
SLS-CLASS	197		Body	WSS - Weight sensing system																																	
SLS-CLASS	197		Body	SCM [MRM] - Steering column module																																	
SLS-CLASS	197		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLS-CLASS	197		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
SLS-CLASS	197		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
SLS-CLASS	197		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLS-CLASS	197		Body	EZS/EIS - Electronic ignition lock																																	
SLS-CLASS	197		Body	CGW - Central gateway																																	
SLS-CLASS	197		Body	AB - Airbag																																	
SLS-CLASS	197		Information	MFK - Multifunction camera																																	
SLS-CLASS	197		Information	SGR - Radar sensors control unit																																	
SLS-CLASS	197		Information	ZAN - Audio/COMAND display																																	
SLS-CLASS	197		Information	SOUND - Sound system																																	
SLS-CLASS	197		Information	PTS - Parktronic system																																	
SLS-CLASS	197		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLS-CLASS	197		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLS-CLASS	197		Information	MIF/UCI - Media interface																																	
SLS-CLASS	197		Information	IC - Instrument cluster																																	
SLS-CLASS	197		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLS-CLASS	197		Information	DAB/SDAR - Digital/Satellite radio																																	
SLS-CLASS	197		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLS-CLASS	197		Information	AUDIO/COMAND																																	
SLS-CLASS	197		Information	AMG Performance Media																																	
SLS-CLASS	197		Seat/Door	RVC/VDS - Convertible roof control																						V		V									
SLS-CLASS	197		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																				V													
SLS-CLASS	197		Seat/Door	ESA Driver - Electric seat adjustment Driver																				V													
SLS-CLASS	197		Seat/Door	DCM-FR - Door control module front right																				V			V								V	
SLS-CLASS	197		Seat/Door	DCM-FL - Door control module front left																				V			V								V	
SLS-CLASS	197		Air Conditioning	AAC - Automatic air conditioning																					V												
AMG GT	190		Drive	DTR - Distronic																																	
AMG GT	190		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
AMG GT	190		Drive	DSI - Direct select interface																																	
AMG GT	190		Drive	AMG DRIVE UNIT																																	
AMG GT	190		Drive	PTCU - Common powertrain controller																																	
AMG GT	190		Drive	ME/CDI/CNG - Engine control unit				V																													
AMG GT	190		Drive	ETC - Electronic transmission control																																	
AMG GT	190		Chassis	TPM - Tire pressure monitor																																	
AMG GT	190		Chassis	Suspension											V																						
AMG GT	190		Chassis	ABS/ESP - Electronic stability program																																	
AMG GT	190		Chassis	EFB - Electric parking brake														V				V															
AMG GT	190		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
AMG GT	190		Information	DAB/SDAR - Digital/Satellite radio																																	
AMG GT	190		Information	SOUND - Sound system																																	
AMG GT	190		Information	RFK - Backup camera																																	
AMG GT	190		Information	PTS - Parktronic system																																	
AMG GT	190		Information	MFK - Multifunction camera																																	
AMG GT	190		Information	IC - Instrument cluster																																	
AMG GT	190		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
AMG GT	190		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
AMG GT	190		Information	AUDIO/COMAND																																	
AMG GT	190		Information	ZAN - Audio/COMAND display																																	
AMG GT	190		Information	COU [ZBE] - Audio/COMAND operating unit																																	
AMG GT	190		Information	DTA - Mbrace or TELEAID/GPS Box																																	
AMG GT	190		Information	AMG Performance Media																																	
AMG GT	190		Body	SCM [MRM] - Steering column module																																	
AMG GT	190		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
AMG GT	190		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																	V																
AMG GT	190		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
AMG GT	190		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
AMG GT	190		Body	AB - Airbag																																	
AMG GT	190		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
AMG GT	190		Body	Headlamp-R - Headlamp control unit																																	
AMG GT	190		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
AMG GT	190		Body	SG-AWF - Collision prevention assist																																	
AMG GT	190		Body	EZS/EIS - Electronic ignition lock																																	
AMG GT	190		Body	CGW - Central gateway																																	
AMG GT	190		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																				V													
AMG GT	190		Seat/Door	ESA Driver - Electric seat adjustment Driver																				V													
AMG GT	190		Seat/Door	DCM-FR - Door control module front right																				V			V								V	
AMG GT	190		Seat/Door	DCM-FL - Door control module front left																				V			V								V	
AMG GT	190		Air Conditioning	AAC - Automatic air conditioning																					V												
SLR-CLASS	199		Drive	ME/CDI/CNG - Engine control unit																																	
SLR-CLASS	199		Drive	ETC - Electronic transmission control						V	V	V																									
SLR-CLASS	199		Drive	ESM - Electronic selector module																																	
SLR-CLASS	199		Chassis	ABS/ESP - Electronic stability program																																	
SLR-CLASS	199		Chassis	SBC - Sensotronic Brake Control																																	
SLR-CLASS	199		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
SLR-CLASS	199		Body	WSS - Weight sensing system																																	
SLR-CLASS	199		Body	SCM [MRM] - Steering column module																																	
SLR-CLASS	199		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLR-CLASS	199		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SLR-CLASS	199		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLR-CLASS	199		Body	OCP - Overhead control panel																																	
SLR-CLASS	199		Body	LCP/HBF - Lower/Rear control panel																																	
SLR-CLASS	199		Body	Headlamp-R - Headlamp control unit																																	
SLR-CLASS	199		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLR-CLASS	199		Body	EZS/EIS - Electronic ignition lock																																	
SLR-CLASS	199		Body	CGW - Central gateway																																	
SLR-CLASS	199		Body	BNS/BMS - Battery sensor																																	
SLR-CLASS	199		Body	AB - Airbag																																	
SLR-CLASS	199		Information	IC - Instrument cluster																				V													
SLR-CLASS	199		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLR-CLASS	199		Information	AUDIO/COMAND																																	
SLR-CLASS	199		Seat/Door	DCM-FR - Door control module front right																																	
SLR-CLASS	199		Seat/Door	DCM-FL - Door control module front left																																	
SLR-CLASS	199		Air Conditioning	AAC - Automatic air conditioning																																	
MAYBACH	240		Drive	ME/CDI/CNG - Engine control unit			V	V																													
MAYBACH	240		Drive	ETC - Electronic transmission control						V	V	V																									
MAYBACH	240		Drive	ESM - Electronic selector module																																	
MAYBACH	240		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
MAYBACH	240		Drive	DTR - Distronic																																	
MAYBACH	240		Chassis	ABS/ESP - Electronic stability program																																	
MAYBACH	240		Chassis	Suspension																																	
MAYBACH	240		Chassis	SBC - Sensotronic Brake Control																																	
MAYBACH	240		Chassis	TPM - Tire pressure monitor																																	
MAYBACH	240		Body	WSS - Weight sensing system																																	
MAYBACH	240		Body	System diagnosis																																	
MAYBACH	240		Body	SCM [MRM] - Steering column module																																	
MAYBACH	240		Body	HSW/LRH - Steering wheel heater																																	
MAYBACH	240		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
MAYBACH	240		Body	AB - Airbag																																	
MAYBACH	240		Information	TV - TV tuner																																	
MAYBACH	240		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
MAYBACH	240		Information	DTA - Mbrace or TELEAID/GPS Box																																	
MAYBACH	240		Information	AGW - Audio gateway																																	
MAYBACH	240		Seat/Door	REDC/RWT - Rear end door control module																																	V
MAYBACH	240		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All_Model(BETA)	16P Connector		Drive	SG-EM - Power electronics																																	
All_Model(BETA)	16P Connector		Drive	HFPM - Haptic accelerator pedal module																																	
All_Model(BETA)	16P Connector		Drive	ME/CDI/CNG - Engine control unit			V	V																													
All_Model(BETA)	16P Connector		Drive	ETC - Electronic transmission control						V	V	V																									
All_Model(BETA)	16P Connector		Drive	ESM - Electronic selector module																																	
All_Model(BETA)	16P Connector		Drive	VG - Transfer case									V																								
All_Model(BETA)	16P Connector		Drive	VECU - Power monitoring control unit																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-B - Electric motor control unit B																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-A - Electric motor control unit A																																	
All_Model(BETA)	16P Connector		Drive	SCR - Selective catalytic reduction																																	
All_Model(BETA)	16P Connector		Drive	PTCU - Common powertrain controller																																	
All_Model(BETA)	16P Connector		Drive	Natural gas control unit																																	
All_Model(BETA)	16P Connector		Drive	ISM - Intelligent servo module																																	
All_Model(BETA)	16P Connector		Drive	Hydrogen tank control unit																																	
All_Model(BETA)	16P Connector		Drive	HSG - Hybrid control unit																		V															
All_Model(BETA)	16P Connector		Drive	High-temperature coolant pump control unit																																	
All_Model(BETA)	16P Connector		Drive	Fuel cell control unit																																	
All_Model(BETA)	16P Connector		Drive	FSCU-R - Control unit fuel pump																																	
All_Model(BETA)	16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
All_Model(BETA)	16P Connector		Drive	EMPI - Electronic Motor Pump Inverter																																	
All_Model(BETA)	16P Connector		Drive	Electric drive control unit																																	
All_Model(BETA)	16P Connector		Drive	DTR - Distronic																V																	
All_Model(BETA)	16P Connector		Drive	DSI - Direct select interface																																	
All_Model(BETA)	16P Connector		Drive	Compressed Natural Gas Control Module																																	
All_Model(BETA)	16P Connector		Drive	CC - Cruise control																																	
All_Model(BETA)	16P Connector		Drive	BSA - Belt-driven starter/alternator																																	
All_Model(BETA)	16P Connector		Drive	AMG DRIVE UNIT																																	
All_Model(BETA)	16P Connector		Drive	ACS - Automatic clutch system																																	
All_Model(BETA)	16P Connector		Chassis	ABS/ESP - Electronic stability program					V																												
All_Model(BETA)	16P Connector		Chassis	Suspension		V									V		V																				
All_Model(BETA)	16P Connector		Chassis	SBC - Sensotronic Brake Control																																	
All_Model(BETA)	16P Connector		Chassis	PSE - Pneumatic system equipment																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
All_Model(BETA)	16P Connector		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
All_Model(BETA)	16P Connector		Chassis	HAQ - Interwheel differential lock at rear axle																																	
All_Model(BETA)	16P Connector		Chassis	FWGW - Chassis gateway																																	
All_Model(BETA)	16P Connector		Chassis	ES - Electrical power steering																																	
All_Model(BETA)	16P Connector		Chassis	EFB - Electric parking brake														V				V															
All_Model(BETA)	16P Connector		Chassis	BAS - Brake assist																																	
All_Model(BETA)	16P Connector		Chassis	VP - Vacuum pump brake booster																																	
All_Model(BETA)	16P Connector		Chassis	TPM - Tire pressure monitor																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
All_Model(BETA)	16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
All_Model(BETA)	16P Connector		Body	CSHV - Crash sensor/high-voltage battery																																	
All_Model(BETA)	16P Connector		Body	WSS - Weight sensing system																																	
All_Model(BETA)	16P Connector		Body	UCP - Upper control panel																																	
All_Model(BETA)	16P Connector		Body	System diagnosis																																	
All_Model(BETA)	16P Connector		Body	SG-DDW - DC/DC converter control unit																																	
All_Model(BETA)	16P Connector		Body	SG-AWF - Collision prevention assist																																	
All_Model(BETA)	16P Connector		Body	SCM [MRM] - Steering column module																																	
All_Model(BETA)	16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
All_Model(BETA)	16P Connector		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
All_Model(BETA)	16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																V	V																
All_Model(BETA)	16P Connector		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
All_Model(BETA)	16P Connector		Body	RevETR-LF - Left front reversible emergency tensioning retractor												V																					
All_Model(BETA)	16P Connector		Body	RCM - Rear control module																																	
All_Model(BETA)	16P Connector		Body	OCP - Overhead control panel																																	
All_Model(BETA)	16P Connector		Body	Multifunction control unit																																	
All_Model(BETA)	16P Connector		Body	LCP/HBF - Lower/Rear control panel																																	
All_Model(BETA)	16P Connector		Body	LAE [LAA] - Loading floor automatically extendable																																	
All_Model(BETA)	16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking	V																																
All_Model(BETA)	16P Connector		Body	HSW/LRH - Steering wheel heater																																	
All_Model(BETA)	16P Connector		Body	Headlamp-R - Headlamp control unit																																	
All_Model(BETA)	16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
All_Model(BETA)	16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
All_Model(BETA)	16P Connector		Body	CGW - Central gateway																																	
All_Model(BETA)	16P Connector		Body	BNS/BMS - Battery sensor																																	
All_Model(BETA)	16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
All_Model(BETA)	16P Connector		Body	AHE - Trailer recognition																																	
All_Model(BETA)	16P Connector		Body	AB - Airbag																																	
All_Model(BETA)	16P Connector		Body	AAM - All activity module																																	
All_Model(BETA)	16P Connector		Information	TPAD - Touchpad																																	
All_Model(BETA)	16P Connector		Information	Head-up display																																	
All_Model(BETA)	16P Connector		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
All_Model(BETA)	16P Connector		Information	KAB - Camera cover																																	
All_Model(BETA)	16P Connector		Information	ZAN - Audio/COMAND display																																	
All_Model(BETA)	16P Connector		Information	VCS - Voice control																																	
All_Model(BETA)	16P Connector		Information	TV - TV tuner																																	
All_Model(BETA)	16P Connector		Information	Tuner - Standard tuner																																	
All_Model(BETA)	16P Connector		Information	Sound generator for exhaust system																																	
All_Model(BETA)	16P Connector		Information	SOUND - Sound system																																	
All_Model(BETA)	16P Connector		Information	SGR - Radar sensors control unit																																	
All_Model(BETA)	16P Connector		Information	360' - Camera																																	
All_Model(BETA)	16P Connector		Information	MFK - Multifunction camera																																	
All_Model(BETA)	16P Connector		Information	RFK - Backup camera																																	
All_Model(BETA)	16P Connector		Information	PTS - Parktronic system																																	
All_Model(BETA)	16P Connector		Information	NSA - Night View Assist																																	
All_Model(BETA)	16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-RF - Right front range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LF - Left front range radar																																	
All_Model(BETA)	16P Connector		Information	NAV - Navigation module																																	
All_Model(BETA)	16P Connector		Information	MIF/UCI - Media interface																																	
All_Model(BETA)	16P Connector		Information	ICI - InCar Internet																																	
All_Model(BETA)	16P Connector		Information	IC - Instrument cluster																			V	V													
All_Model(BETA)	16P Connector		Information	DVD player																																	
All_Model(BETA)	16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
All_Model(BETA)	16P Connector		Information	D-FOR - Display in right rear passenger																																	
All_Model(BETA)	16P Connector		Information	D-FOL - Display in left rear passenger																																	
All_Model(BETA)	16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
All_Model(BETA)	16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
All_Model(BETA)	16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
All_Model(BETA)	16P Connector		Information	CM - Compass module																																	
All_Model(BETA)	16P Connector		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing
All Model(BETA)	16P Connector		Information	AUDIO/COMAND																																	
All Model(BETA)	16P Connector		Information	ASSYST PLUS - PLUS Active Service System																																	
All Model(BETA)	16P Connector		Information	ASSYST Active Service System																				V													
All Model(BETA)	16P Connector		Information	APS - Auto pilot system																																	
All Model(BETA)	16P Connector		Information	AMG Performance Media																																	
All Model(BETA)	16P Connector		Information	AGW - Audio gateway																																	
All Model(BETA)	16P Connector		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-MR - Right center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-ML - Left center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TLC/GTO - Garage door opener																																	
All Model(BETA)	16P Connector		Seat/Door	RVC/VDS - Convertible roof control																						V		V									
All Model(BETA)	16P Connector		Seat/Door	REDC/RWT - Rear end door control module																																	V
All Model(BETA)	16P Connector		Seat/Door	PSD/MSC - Sliding roof control																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-R - Multicontour backrest rear																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FR - Multicontour backrest front right																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FL - Multicontour backrest front left																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	HS - Seat heater																																	
All Model(BETA)	16P Connector		Seat/Door	HKS - Tailgate control																																	
All Model(BETA)	16P Connector		Seat/Door	ESA-R - Electric seat adjustment rear																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																					V				V	V	V	V	V	V			
All Model(BETA)	16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																					V				V	V	V	V	V	V			
All Model(BETA)	16P Connector		Seat/Door	ERA - Electric fold down backrest system																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-RR - Door control module rear right																					V		V								V		
All Model(BETA)	16P Connector		Seat/Door	DCM-RL - Door control module rear left																					V		V								V		
All Model(BETA)	16P Connector		Seat/Door	DCM-FR - Door control module front right																V					V		V								V		
All Model(BETA)	16P Connector		Seat/Door	DCM-FL - Door control module front left																V					V		V								V		
All Model(BETA)	16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control										V																							
All Model(BETA)	16P Connector		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
All Model(BETA)	16P Connector		Air Conditioning	HBF - Rear control panel																																	
All Model(BETA)	16P Connector		Air Conditioning	HB - Heater booster																																	
All Model(BETA)	16P Connector		Air Conditioning	EKMK - Electric refrigerant compressor																																	
All Model(BETA)	16P Connector		Air Conditioning	AAC - Automatic air conditioning															V							V											

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
A-CLASS	68		Drive	ME/CDI/CNG - Engine control unit																																	
A-CLASS	68		Drive	ETC - Electronic transmission control																					V												
A-CLASS	68		Drive	ESM - Electronic selector module																																	
A-CLASS	68		Drive	ACS - Automatic clutch system																																	
A-CLASS	68		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Chassis	ABS/ESP - Electronic stability program																							V										
A-CLASS	168		Body	LCP/HBF - Lower/Rear control panel																																	
A-CLASS	168		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	168		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	168		Body	AB - Airbag																																	
A-CLASS	168		Information	PTS - Parktronic system																																	
A-CLASS	168		Information	IC - Instrument cluster								V					V																				
A-CLASS	168		Information	AUDIO/COMAND																																	
A-CLASS	168		Information	APS - Auto pilot system																																	
A-CLASS	168		Seat/Door	DCM-RR - Door control module rear right																				V													
A-CLASS	168		Seat/Door	DCM-RL - Door control module rear left																				V													
A-CLASS	168		Seat/Door	DCM-FR - Door control module front right																				V													
A-CLASS	168		Seat/Door	DCM-FL - Door control module front left																				V													
A-CLASS	168		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	168		Air Conditioning	HB - Heater booster																																	
A-CLASS	168		Air Conditioning	AAC - Automatic air conditioning							V																										
A-CLASS	169		Drive	ME/CDI/CNG - Engine control unit											V	V			V										V	V		V	V	V			V
A-CLASS	169		Drive	ETC - Electronic transmission control																																	
A-CLASS	169		Drive	ESM - Electronic selector module																																	
A-CLASS	169		Drive	BSA - Belt-driven starter/alternator																																	
A-CLASS	169		Chassis	ABS/ESP - Electronic stability program																	V																
A-CLASS	169		Chassis	ES - Electrical power steering																																	
A-CLASS	169		Body	SCM [MRM] - Steering column module																																	
A-CLASS	169		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																								V									
A-CLASS	169		Body	OCP - Overhead control panel	V																																
A-CLASS	169		Body	Multifunction control unit																																	
A-CLASS	169		Body	Headlamp-R - Headlamp control unit																																	
A-CLASS	169		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
A-CLASS	169		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	169		Body	CGW - Central gateway																																	
A-CLASS	169		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
A-CLASS	169		Body	AHE - Trailer recognition																																	
A-CLASS	169		Body	AB - Airbag																																	
A-CLASS	169		Information	SOUND - Sound system																																	
A-CLASS	169		Information	PTS - Parktronic system																																	
A-CLASS	169		Information	MIF/UCI - Media interface																																	
A-CLASS	169		Information	IC - Instrument cluster									V	V																							
A-CLASS	169		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	169		Information	CTEL/TEL - Cellular/Mobile telephone																																	
A-CLASS	169		Information	AUDIO/COMAND																																	
A-CLASS	169		Information	ASSYST PLUS - PLUS Active Service System																																	
A-CLASS	169		Information	ASSYST Active Service System									V																								
A-CLASS	169		Information	AGW - Audio gateway																																	
A-CLASS	169		Seat/Door	DCM-RR - Door control module rear right																				V													
A-CLASS	169		Seat/Door	DCM-RL - Door control module rear left																				V													
A-CLASS	169		Seat/Door	DCM-FR - Door control module front right																				V													
A-CLASS	169		Seat/Door	DCM-FL - Door control module front left																				V													
A-CLASS	169		Air Conditioning	AAC - Automatic air conditioning							V																										
A-CLASS	176		Drive	VG - Transfer case																																	
A-CLASS	176		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
A-CLASS	176		Drive	ETC - Electronic transmission control																																	
A-CLASS	176		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
A-CLASS	176		Drive	DTR - Distronic																																	
A-CLASS	176		Drive	DSI - Direct select interface																																	
A-CLASS	176		Drive	PTCU - Common powertrain controller																																	
A-CLASS	176		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	176		Chassis	ES - Electrical power steering																																	
A-CLASS	176		Chassis	EFB - Electric parking brake																																	
A-CLASS	176		Chassis	TPM - Tire pressure monitor																																	
A-CLASS	176		Body	SG-AWF - Collision prevention assist																																	
A-CLASS	176		Body	SCM [MRM] - Steering column module																																	
A-CLASS	176		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
A-CLASS	176		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	Multifunction control unit																																	
A-CLASS	176		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	176		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
A-CLASS	176		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	176		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	176		Body	AHE - Trailer recognition																																	
A-CLASS	176		Body	AB - Airbag																																	
A-CLASS	176		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
A-CLASS	176		Information	ZAN - Audio/COMAND display																																	
A-CLASS	176		Information	TV - TV tuner																																	
A-CLASS	176		Information	SOUND - Sound system																																	
A-CLASS	176		Information	RFK - Backup camera																																	
A-CLASS	176		Information	MFK - Multifunction camera																																	
A-CLASS	176		Information	PTS - Parktronic system																																	
A-CLASS	176		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
A-CLASS	176		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
A-CLASS	176		Information	NAV - Navigation module																																	
A-CLASS	176		Information	MIF/UCI - Media interface																																	
A-CLASS	176		Information	IC - Instrument cluster																														V			
A-CLASS	176		Information	DTA - Mbrace or TELEAID/GPS Box																																	
A-CLASS	176		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	176		Information	COU [ZBE] - Audio/COMAND operating unit																																	
A-CLASS	176		Information	AUDIO/COMAND																																	
A-CLASS	176		Seat/Door	PSD/MSC - Sliding roof control																																	
A-CLASS	176		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
A-CLASS	176		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
A-CLASS	176		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	176		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	176		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	176		Air Conditioning	AAC - Automatic air conditioning																			V														
B-CLASS	245		Drive	ME/CDI/CNG - Engine control unit															V											V		V					V
B-CLASS	245		Drive	ETC - Electronic transmission control																																	
B-CLASS	245		Drive	ESM - Electronic selector module																																	
B-CLASS	245		Drive	Hydrogen tank control unit																																	
B-CLASS	245		Drive	High-temperature coolant pump control unit																																	
B-CLASS	245		Drive	Fuel cell control unit																																	
B-CLASS	245		Drive	Electric drive control unit																																	
B-CLASS	245		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	245		Drive	BSA - Belt-driven starter/alternator																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
B-CLASS	245		Drive	VECU - Power monitoring control unit																																	
B-CLASS	245		Chassis	ABS/ESP - Electronic stability program																	V																
B-CLASS	245		Chassis	ES - Electrical power steering																																	
B-CLASS	245		Chassis	VP - Vacuum pump brake booster																																	
B-CLASS	245		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	245		Body	WSS - Weight sensing system																																	
B-CLASS	245		Body	SG-DDW - DC/DC converter control unit																																	
B-CLASS	245		Body	SCM [MRM] - Steering column module																																	
B-CLASS	245		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																							V										
B-CLASS	245		Body	OCP - Overhead control panel	V																																
B-CLASS	245		Body	Multifunction control unit																																	
B-CLASS	245		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	245		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	245		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	245		Body	CGW - Central gateway																																	
B-CLASS	245		Body	BNS/BMS - Battery sensor																																	
B-CLASS	245		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	245		Body	AHE - Trailer recognition																																	
B-CLASS	245		Body	AB - Airbag																																	
B-CLASS	245		Information	SOUND - Sound system																																	
B-CLASS	245		Information	PTS - Parktronic system																																	
B-CLASS	245		Information	NAV - Navigation module																																	
B-CLASS	245		Information	MIF/UCI - Media interface																																	
B-CLASS	245		Information	IC - Instrument cluster									V	V																							
B-CLASS	245		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	245		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	245		Information	CTEL/TEL - Cellular/Mobile telephone																																	
B-CLASS	245		Information	CM - Compass module																																	
B-CLASS	245		Information	AUDIO/COMAND																																	
B-CLASS	245		Information	ASSYST PLUS - PLUS Active Service System																																	
B-CLASS	245		Information	ASSYST Active Service System									V																								
B-CLASS	245		Information	AGW - Audio gateway																																	
B-CLASS	245		Seat/Door	DCM-RR - Door control module rear right																				V													
B-CLASS	245		Seat/Door	DCM-RL - Door control module rear left																				V													
B-CLASS	245		Seat/Door	DCM-FR - Door control module front right																				V													
B-CLASS	245		Seat/Door	DCM-FL - Door control module front left																				V													

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
B-CLASS	245		Air Conditioning	EKMK - Electric refrigerant compressor																																	
B-CLASS	245		Air Conditioning	AAC - Automatic air conditioning							V																										
B-CLASS	246		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	246		Drive	VG - Transfer case																																	
B-CLASS	246		Drive	ME/CDI/CNG - Engine control unit											V	V												V			V	V	V			V
B-CLASS	246		Drive	ETC - Electronic transmission control																																	
B-CLASS	246		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
B-CLASS	246		Drive	DTR - Distronic																																	
B-CLASS	246		Drive	PTCU - Common powertrain controller																																	
B-CLASS	246		Chassis	ABS/ESP - Electronic stability program																																	
B-CLASS	246		Chassis	ES - Electrical power steering																																	
B-CLASS	246		Chassis	EFB - Electric parking brake																																	
B-CLASS	246		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	246		Body	BNS/BMS - Battery sensor																																	
B-CLASS	246		Body	SG-AWF - Collision prevention assist																																	
B-CLASS	246		Body	SCM [MRM] - Steering column module																																	
B-CLASS	246		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
B-CLASS	246		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	Multifunction control unit																																	
B-CLASS	246		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
B-CLASS	246		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	246		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	246		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	246		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	246		Body	AHE - Trailer recognition																																	
B-CLASS	246		Body	AB - Airbag																																	
B-CLASS	246		Information	Sound generator for exhaust system																																	
B-CLASS	246		Information	Head-up display																																	
B-CLASS	246		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
B-CLASS	246		Information	ZAN - Audio/COMAND display																																	
B-CLASS	246		Information	TV - TV tuner																																	
B-CLASS	246		Information	SOUND - Sound system																																	
B-CLASS	246		Information	RFK - Backup camera																																	
B-CLASS	246		Information	MFK - Multifunction camera																																	
B-CLASS	246		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
B-CLASS	246		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
B-CLASS	246		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
B-CLASS	246		Information	NAV - Navigation module																																	
B-CLASS	246		Information	MIF/UCI - Media interface																																	
B-CLASS	246		Information	IC - Instrument cluster																															V		
B-CLASS	246		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	246		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	246		Information	COU [ZBE] - Audio/COMAND operating unit																																	
B-CLASS	246		Information	AUDIO/COMAND																																	
B-CLASS	246		Seat/Door	PSD/MSC - Sliding roof control																																	
B-CLASS	246		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
B-CLASS	246		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
B-CLASS	246		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	246		Seat/Door	DCM-FL - Door control module front left																																	
B-CLASS	246		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
B-CLASS	246		Air Conditioning	AAC - Automatic air conditioning																			V														
C-CLASS	202		Drive	ME/CDI/CNG - Engine control unit																										V							
C-CLASS	202		Drive	ETC - Electronic transmission control																					V												
C-CLASS	202		Drive	ESM - Electronic selector module																																	
C-CLASS	202		Chassis	PSE - Pneumatic system equipment																																	
C-CLASS	202		Chassis	ABS/ESP - Electronic stability program																							V										
C-CLASS	202		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	202		Chassis	BAS - Brake assist																																	
C-CLASS	202		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	202		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	202		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	202		Body	OCP - Overhead control panel																																	
C-CLASS	202		Body	AB - Airbag																																	
C-CLASS	202		Information	PTS - Parktronic system																																	
C-CLASS	202		Information	NAV - Navigation module																																	
C-CLASS	202		Information	IC - Instrument cluster								V					V																				
C-CLASS	202		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	202		Information	AUDIO/COMAND																																	
C-CLASS	202		Information	APS - Auto pilot system																																	
C-CLASS	202		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	202		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
C-CLASS	202		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	202		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	202		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	202		Air Conditioning	HB - Heater booster																																	
C-CLASS	202		Air Conditioning	AAC - Automatic air conditioning							V																										
C-CLASS	203		Drive	ME/CDI/CNG - Engine control unit															V										V		V						V
C-CLASS	203		Drive	ETC - Electronic transmission control																					V												
C-CLASS	203		Drive	ESM - Electronic selector module																																	
C-CLASS	203		Drive	DTR - Distronic																																	
C-CLASS	203		Chassis	ABS/ESP - Electronic stability program																	V																
C-CLASS	203		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	203		Chassis	BAS - Brake assist																																	
C-CLASS	203		Body	WSS - Weight sensing system																																	
C-CLASS	203		Body	UCP - Upper control panel																																	
C-CLASS	203		Body	System diagnosis																																	
C-CLASS	203		Body	SCM [MRM] - Steering column module																																	
C-CLASS	203		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	203		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																								V									
C-CLASS	203		Body	OCP - Overhead control panel	V																																
C-CLASS	203		Body	Multifunction control unit																																	
C-CLASS	203		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	203		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	203		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	203		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	203		Body	CGW - Central gateway																																	
C-CLASS	203		Body	AHE - Trailer recognition																																	
C-CLASS	203		Body	AB - Airbag																																	
C-CLASS	203		Information	TV - TV tuner																																	
C-CLASS	203		Information	SOUND - Sound system																																	
C-CLASS	203		Information	PTS - Parktronic system																																	
C-CLASS	203		Information	NAV - Navigation module																																	
C-CLASS	203		Information	MIF/UCI - Media interface																																	
C-CLASS	203		Information	IC - Instrument cluster								V	V			V																			V	
C-CLASS	203		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	203		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	203		Information	CTEL/TEL - Cellular/Mobile telephone																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
C-CLASS	203		Information	AUDIO/COMAND																																	
C-CLASS	203		Information	AGW - Audio gateway																																	
C-CLASS	203		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger		V	V	V	V	V																											
C-CLASS	203		Seat/Door	ESA Driver - Electric seat adjustment Driver		V	V	V	V	V																											
C-CLASS	203		Seat/Door	DCM-RR - Door control module rear right																				V													
C-CLASS	203		Seat/Door	DCM-RL - Door control module rear left																				V													
C-CLASS	203		Seat/Door	DCM-FR - Door control module front right																				V													
C-CLASS	203		Seat/Door	DCM-FL - Door control module front left																				V													
C-CLASS	203		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	203		Air Conditioning	AAC - Automatic air conditioning							V																										
C-CLASS	204		Drive	ME/CDI/CNG - Engine control unit											V	V			V										V	V		V	V	V			V
C-CLASS	204		Drive	ETC - Electronic transmission control																					V												
C-CLASS	204		Drive	ESM - Electronic selector module																																	
C-CLASS	204		Drive	SCR - Selective catalytic reduction																																	
C-CLASS	204		Drive	ISM - Intelligent servo module																																	
C-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
C-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	204		Drive	DTR - Distronic																																	
C-CLASS	204		Drive	AMG DRIVE UNIT																																	
C-CLASS	204		Drive	PTCU - Common powertrain controller																																	
C-CLASS	204		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	204		Chassis	Suspension																																	
C-CLASS	204		Chassis	ES - Electrical power steering																																	
C-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	204		Body	WSS - Weight sensing system																																	
C-CLASS	204		Body	SCM [MRM] - Steering column module																																	
C-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	OCP - Overhead control panel																																	
C-CLASS	204		Body	Multifunction control unit																																	
C-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	204		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
C-CLASS	204		Body	CGW - Central gateway																																	
C-CLASS	204		Body	AHE - Trailer recognition																																	
C-CLASS	204		Body	AB - Airbag																																	
C-CLASS	204		Information	Head-up display																																	
C-CLASS	204		Information	AVE-H - Rear audio video unit																																	
C-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
C-CLASS	204		Information	ZAN - Audio/COMAND display																																	
C-CLASS	204		Information	TV - TV tuner																																	
C-CLASS	204		Information	Sound generator for exhaust system																																	
C-CLASS	204		Information	SOUND - Sound system																																	
C-CLASS	204		Information	SGR - Radar sensors control unit																																	
C-CLASS	204		Information	360' - Camera																																	
C-CLASS	204		Information	MFK - Multifunction camera																																	
C-CLASS	204		Information	RFK - Backup camera																																	
C-CLASS	204		Information	PTS - Parktronic system																																	
C-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	204		Information	NBR-RF - Right front range radar																																	
C-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	204		Information	NBR-LF - Left front range radar																																	
C-CLASS	204		Information	NAV - Navigation module																																	
C-CLASS	204		Information	MIF/UCI - Media interface																																	
C-CLASS	204		Information	ICI - InCar Internet																																	
C-CLASS	204		Information	IC - Instrument cluster																														V			
C-CLASS	204		Information	DVD player																																	
C-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
C-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
C-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
C-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	204		Information	AUDIO/COMAND																																	
C-CLASS	204		Information	AMG Performance Media																																	
C-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	204		Seat/Door	HKS - Tailgate control																																	
C-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
C-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	204		Air Conditioning	AAC - Automatic air conditioning																			V														
C-CLASS	205		Drive	SCR - Selective catalytic reduction																																	
C-CLASS	205		Drive	SG-EM - Power electronics																																	
C-CLASS	205		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	205		Drive	HFPM - Haptic accelerator pedal module																																	
C-CLASS	205		Drive	DTR - Distronic																																	
C-CLASS	205		Drive	ISM - Intelligent servo module																																	
C-CLASS	205		Drive	ME/CDI/CNG - Engine control unit											V	V													V		V	V	V			V
C-CLASS	205		Drive	ETC - Electronic transmission control																																	
C-CLASS	205		Drive	PTCU - Common powertrain controller																																	
C-CLASS	205		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	205		Chassis	Suspension																																	
C-CLASS	205		Chassis	ABS/ESP - Electronic stability program																V																	
C-CLASS	205		Chassis	ES - Electrical power steering																																	
C-CLASS	205		Chassis	EFB - Electric parking brake																																	
C-CLASS	205		Information	TPAD - Touchpad																																	
C-CLASS	205		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	205		Information	360' - Camera																																	
C-CLASS	205		Information	Sound generator for exhaust system																																	
C-CLASS	205		Information	SOUND - Sound system																																	
C-CLASS	205		Information	RFK - Backup camera																																	
C-CLASS	205		Information	SGR - Radar sensors control unit																																	
C-CLASS	205		Information	PTS - Parktronic system																																	
C-CLASS	205		Information	NBR-RF - Right front range radar																																	
C-CLASS	205		Information	NBR-LF - Left front range radar																																	
C-CLASS	205		Information	MFK - Multifunction camera																																	
C-CLASS	205		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	205		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	205		Information	Head-up display																																	
C-CLASS	205		Information	AUDIO/COMAND																																	
C-CLASS	205		Information	ZAN - Audio/COMAND display																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
C-CLASS	205		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	205		Information	KAB - Camera cover																																	
C-CLASS	205		Information	IC - Instrument cluster																														V			
C-CLASS	205		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	205		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
C-CLASS	205		Body	AHE - Trailer recognition																																	
C-CLASS	205		Body	SCM [MRM] - Steering column module																																	
C-CLASS	205		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	AB - Airbag																																	
C-CLASS	205		Body	Multifunction control unit																																	
C-CLASS	205		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	205		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	205		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	205		Body	SG-AWF - Collision prevention assist																																	
C-CLASS	205		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	205		Body	BNS/BMS - Battery sensor																																	
C-CLASS	205		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	205		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	205		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	205		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	205		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	205		Seat/Door	HKS - Tailgate control																																	
C-CLASS	205		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	205		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	205		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	205		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	205		Seat/Door	RVC/VDS - Convertible roof control																																	
C-CLASS	205		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	124		Drive	PMS/HFM/LH																																	
E-CLASS	124		Drive	ETC - Electronic transmission control																																	
E-CLASS	124		Drive	ISC - Idle speed control																																	
E-CLASS	124		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	124		Body	AB - Airbag																																	
E-CLASS	210		Drive	ME/CDI/CNG - Engine control unit																										V							
E-CLASS	210		Drive	ETC - Electronic transmission control																					V												

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
E-CLASS	210		Drive	ESM - Electronic selector module																																	
E-CLASS	210		Chassis	ABS/ESP - Electronic stability program																							V										
E-CLASS	210		Chassis	VP - Vacuum pump brake booster																																	
E-CLASS	210		Chassis	PSE - Pneumatic system equipment																																	
E-CLASS	210		Chassis	BAS - Brake assist																																	
E-CLASS	210		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	210		Body	OCP - Overhead control panel																																	
E-CLASS	210		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	210		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	210		Body	AB - Airbag																																	
E-CLASS	210		Information	TV - TV tuner																																	
E-CLASS	210		Information	PTS - Parktronic system																																	
E-CLASS	210		Information	NAV - Navigation module																																	
E-CLASS	210		Information	IC - Instrument cluster								V	V				V																			V	
E-CLASS	210		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	210		Information	AUDIO/COMAND																																	
E-CLASS	210		Information	APS - Auto pilot system																																	
E-CLASS	210		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	210		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	210		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	210		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	210		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	210		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	210		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	210		Air Conditioning	HB - Heater booster																																	
E-CLASS	210		Air Conditioning	AAC - Automatic air conditioning							V																										
E-CLASS	211		Drive	ME/CDI/CNG - Engine control unit															V										V		V						V
E-CLASS	211		Drive	ETC - Electronic transmission control																					V												
E-CLASS	211		Drive	ESM - Electronic selector module																																	
E-CLASS	211		Drive	Natural gas control unit																																	
E-CLASS	211		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	211		Drive	DTR - Distronic																																	
E-CLASS	211		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	211		Chassis	ABS/ESP - Electronic stability program																	V																
E-CLASS	211		Chassis	Suspension																																	
E-CLASS	211		Chassis	SBC - Sensotronic Brake Control																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
E-CLASS	211		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	211		Body	WSS - Weight sensing system																																	
E-CLASS	211		Body	UCP - Upper control panel																																	
E-CLASS	211		Body	System diagnosis																																	
E-CLASS	211		Body	SCM [MRM] - Steering column module																																	
E-CLASS	211		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	211		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
E-CLASS	211		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																							V										
E-CLASS	211		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	OCP - Overhead control panel	V																																
E-CLASS	211		Body	Multifunction control unit																																	
E-CLASS	211		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	211		Body	LAE [LAA] - Loading floor automatically extendable																																	
E-CLASS	211		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	211		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	211		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	211		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	211		Body	CGW - Central gateway																																	
E-CLASS	211		Body	BNS/BMS - Battery sensor																																	
E-CLASS	211		Body	AHE - Trailer recognition																																	
E-CLASS	211		Body	AB - Airbag																																	
E-CLASS	211		Information	TV - TV tuner																																	
E-CLASS	211		Information	SOUND - Sound system																																	
E-CLASS	211		Information	PTS - Parktronic system																																	
E-CLASS	211		Information	MIF/UCI - Media interface																																	
E-CLASS	211		Information	IC - Instrument cluster									V	V																							
E-CLASS	211		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	211		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	211		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	211		Information	AUDIO/COMAND																																	
E-CLASS	211		Information	ASSYST PLUS - PLUS Active Service System																																	
E-CLASS	211		Information	ASSYST Active Service System									V																								
E-CLASS	211		Information	AGW - Audio gateway																																	
E-CLASS	211		Seat/Door	REDC/RWT - Rear end door control module																																	
E-CLASS	211		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
E-CLASS	211		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger		V	V	V	V	V																											
E-CLASS	211		Seat/Door	ESA Driver - Electric seat adjustment Driver		V	V	V	V	V																											
E-CLASS	211		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	211		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DCM-RR - Door control module rear right																				V													
E-CLASS	211		Seat/Door	DCM-RL - Door control module rear left																				V													
E-CLASS	211		Seat/Door	DCM-FR - Door control module front right																				V													
E-CLASS	211		Seat/Door	DCM-FL - Door control module front left																				V													
E-CLASS	211		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	211		Air Conditioning	AAC - Automatic air conditioning							V																										
E-CLASS	207		Drive	SG-EM - Power electronics																																	
E-CLASS	207		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	207		Drive	ME/CDI/CNG - Engine control unit											V	V			V									V	V		V	V	V				V
E-CLASS	207		Drive	ETC - Electronic transmission control																					V												
E-CLASS	207		Drive	ESM - Electronic selector module																																	
E-CLASS	207		Drive	ISM - Intelligent servo module																																	
E-CLASS	207		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	207		Drive	DTR - Distronic																																	
E-CLASS	207		Drive	DSI - Direct select interface																																	
E-CLASS	207		Drive	AMG DRIVE UNIT																																	
E-CLASS	207		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	207		Chassis	Suspension																																	
E-CLASS	207		Chassis	ES - Electrical power steering																																	
E-CLASS	207		Chassis	FWGW - Chassis gateway																																	
E-CLASS	207		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	207		Body	BNS/BMS - Battery sensor																																	
E-CLASS	207		Body	WSS - Weight sensing system																																	
E-CLASS	207		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	207		Body	SCM [MRM] - Steering column module																																	
E-CLASS	207		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	207		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	207		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	207		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	207		Body	Multifunction control unit																																	
E-CLASS	207		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
E-CLASS	207		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
E-CLASS	207		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	207		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	207		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	207		Body	CGW - Central gateway																																	
E-CLASS	207		Body	AHE - Trailer recognition																																	
E-CLASS	207		Body	AB - Airbag																																	
E-CLASS	207		Information	NBR-RF - Right front range radar																																	
E-CLASS	207		Information	NBR-LF - Left front range radar																																	
E-CLASS	207		Information	AVE-H - Rear audio video unit																																	
E-CLASS	207		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	207		Information	ZAN - Audio/COMAND display																																	
E-CLASS	207		Information	TV - TV tuner																																	
E-CLASS	207		Information	SOUND - Sound system																																	
E-CLASS	207		Information	SGR - Radar sensors control unit																																	
E-CLASS	207		Information	360' - Camera																																	
E-CLASS	207		Information	MFK - Multifunction camera																																	
E-CLASS	207		Information	RFK - Backup camera																																	
E-CLASS	207		Information	PTS - Parktronic system																																	
E-CLASS	207		Information	NSA - Night View Assist																																	
E-CLASS	207		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	207		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	207		Information	NAV - Navigation module																																	
E-CLASS	207		Information	MIF/UCI - Media interface																																	
E-CLASS	207		Information	ICI - InCar Internet																																	
E-CLASS	207		Information	IC - Instrument cluster																														V			
E-CLASS	207		Information	DVD player																																	
E-CLASS	207		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	207		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	207		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	207		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	207		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	207		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	207		Information	AUDIO/COMAND																																	
E-CLASS	207		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	207		Seat/Door	PSD/MSC - Sliding roof control																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
E-CLASS	207		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	207		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	207		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	207		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	207		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	207		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	207		Air Conditioning	AAC - Automatic air conditioning																			V														
E-CLASS	212		Drive	SG-EM - Power electronics																																	
E-CLASS	212		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	212		Drive	ME/CDI/CNG - Engine control unit											V	V			V									V	V		V	V	V			V
E-CLASS	212		Drive	ETC - Electronic transmission control																					V												
E-CLASS	212		Drive	ESM - Electronic selector module																																	
E-CLASS	212		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	212		Drive	ISM - Intelligent servo module																																	
E-CLASS	212		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	212		Drive	DTR - Distronic																																	
E-CLASS	212		Drive	DSI - Direct select interface																																	
E-CLASS	212		Drive	AMG DRIVE UNIT																																	
E-CLASS	212		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	212		Chassis	Suspension																																	
E-CLASS	212		Chassis	ES - Electrical power steering																																	
E-CLASS	212		Chassis	FWGW - Chassis gateway																																	
E-CLASS	212		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	212		Body	BNS/BMS - Battery sensor																																	
E-CLASS	212		Body	WSS - Weight sensing system																																	
E-CLASS	212		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	212		Body	SCM [MRM] - Steering column module																																	
E-CLASS	212		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	212		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	212		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	OCP - Overhead control panel																																	
E-CLASS	212		Body	Multifunction control unit																																	
E-CLASS	212		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
E-CLASS	212		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	212		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
E-CLASS	212		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	212		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	212		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	212		Body	CGW - Central gateway																																	
E-CLASS	212		Body	AHE - Trailer recognition																																	
E-CLASS	212		Body	AB - Airbag																																	
E-CLASS	212		Information	Head-up display																																	
E-CLASS	212		Information	AVE-H - Rear audio video unit																																	
E-CLASS	212		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	212		Information	ZAN - Audio/COMAND display																																	
E-CLASS	212		Information	TV - TV tuner																																	
E-CLASS	212		Information	SOUND - Sound system																																	
E-CLASS	212		Information	SGR - Radar sensors control unit																																	
E-CLASS	212		Information	360' - Camera																																	
E-CLASS	212		Information	MFK - Multifunction camera																																	
E-CLASS	212		Information	RFK - Backup camera																																	
E-CLASS	212		Information	PTS - Parktronic system																																	
E-CLASS	212		Information	NSA - Night View Assist																																	
E-CLASS	212		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	212		Information	NBR-RF - Right front range radar																																	
E-CLASS	212		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	212		Information	NBR-LF - Left front range radar																																	
E-CLASS	212		Information	NAV - Navigation module																																	
E-CLASS	212		Information	MIF/UCI - Media interface																																	
E-CLASS	212		Information	ICI - InCar Internet																																	
E-CLASS	212		Information	IC - Instrument cluster																														V			
E-CLASS	212		Information	DVD player																																	
E-CLASS	212		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	212		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	212		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	212		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	212		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	212		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	212		Information	AUDIO/COMAND																																	
E-CLASS	212		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	212		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
E-CLASS	212		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	212		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	212		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	212		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	212		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	212		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	212		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	212		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	212		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	212		Air Conditioning	AAC - Automatic air conditioning																			V														
E-CLASS	213		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	213		Drive	DTR - Distronic																																	
E-CLASS	213		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	213		Drive	HFPM - Haptic accelerator pedal module																																	
E-CLASS	213		Drive	AMG DRIVE UNIT																																	
E-CLASS	213		Drive	PTCU - Common powertrain controller																																	
E-CLASS	213		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
E-CLASS	213		Drive	ETC - Electronic transmission control																																	
E-CLASS	213		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	213		Chassis	AIRMATIC PLUS																																	
E-CLASS	213		Chassis	ES - Electrical power steering																																	
E-CLASS	213		Chassis	Suspension																																	
E-CLASS	213		Chassis	ABS/ESP - Electronic stability program																V																	
E-CLASS	213		Body	MTAS - Mobile phone cradle																																	
E-CLASS	213		Body	AHE - Trailer recognition																																	
E-CLASS	213		Body	SCM [MRM] - Steering column module																																	
E-CLASS	213		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
E-CLASS	213		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
E-CLASS	213		Body	AB - Airbag																																	
E-CLASS	213		Body	OCP - Overhead control panel																																	
E-CLASS	213		Body	Multifunction control unit																																	
E-CLASS	213		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
E-CLASS	213		Body	SG-DDW - DC/DC converter control unit																																	
E-CLASS	213		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	213		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	213		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	213		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	213		Body	BNS/BMS - Battery sensor																																	
E-CLASS	213		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	213		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	213		Body	AML - Ambiance light																																	
E-CLASS	213		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	213		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	213		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
E-CLASS	213		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
E-CLASS	213		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	213		Seat/Door	HKS - Tailgate control																																	
E-CLASS	213		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	213		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	213		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	213		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	213		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	213		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	213		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	213		Information	TPAD - Touchpad																																	
E-CLASS	213		Information	Sound generator for exhaust system																																	
E-CLASS	213		Information	SOUND - Sound system																																	
E-CLASS	213		Information	RFK - Backup camera																																	
E-CLASS	213		Information	PTS - Parktronic system																																	
E-CLASS	213		Information	MFK - Multifunction camera																																	
E-CLASS	213		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	213		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	213		Information	SGR - Radar sensors control unit																																	
E-CLASS	213		Information	IC - Instrument cluster																															V		

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
E-CLASS	213		Information	Head-up display																																	
E-CLASS	213		Information	AUDIO/COMAND																																	
E-CLASS	213		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	213		Information	ZAN - Audio/COMAND display																																	
E-CLASS	213		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	213		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	140		Drive	ASF																																	
S-CLASS	140		Drive	ERE																																	
S-CLASS	140		Drive	ME1LI																																	
S-CLASS	140		Drive	ME1RE																																	
S-CLASS	140		Drive	HFM/ME2/LH																																	
S-CLASS	140		Drive	ETC - Electronic transmission control																																	
S-CLASS	140		Drive	ISC - Idle speed control																																	
S-CLASS	140		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	140		Chassis	BAS - Brake assist																																	
S-CLASS	140		Body	PSE - Pneumatic system equipment																																	
S-CLASS	140		Body	AB - Airbag																																	
S-CLASS	140		Information	PTS - Parktronic system																																	
S-CLASS	140		Information	IC - Instrument cluster																																	
S-CLASS	140		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	220		Drive	ME/CDI/CNG - Engine control unit															V										V		V						V
S-CLASS	220		Drive	ETC - Electronic transmission control																					V												
S-CLASS	220		Drive	ESM - Electronic selector module																																	
S-CLASS	220		Drive	DTR - Distronic																																	
S-CLASS	220		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	220		Chassis	Suspension																		V															
S-CLASS	220		Chassis	PSE - Pneumatic system equipment																																	
S-CLASS	220		Chassis	ABS/ESP - Electronic stability program																							V										
S-CLASS	220		Body	UCP - Upper control panel																																	
S-CLASS	220		Body	System diagnosis																																	
S-CLASS	220		Body	SCM [MRM] - Steering column module																																	
S-CLASS	220		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	220		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
S-CLASS	220		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	220		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	220		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
S-CLASS	220		Body	OCP - Overhead control panel																																	
S-CLASS	220		Body	Multifunction control unit																																	
S-CLASS	220		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	220		Body	HSW/LRH - Steering wheel heater																																	
S-CLASS	220		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	220		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	220		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	220		Body	CGW - Central gateway																																	
S-CLASS	220		Body	AHE - Trailer recognition																																	
S-CLASS	220		Body	AB - Airbag																																	
S-CLASS	220		Information	TV - TV tuner																																	
S-CLASS	220		Information	PTS - Parktronic system																																	
S-CLASS	220		Information	NAV - Navigation module																																	
S-CLASS	220		Information	IC - Instrument cluster								V	V				V																			V	
S-CLASS	220		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	220		Information	AUDIO/COMAND																																	
S-CLASS	220		Information	AGW - Audio gateway																																	
S-CLASS	220		Seat/Door	OSB-R - Multicontour backrest rear																																	
S-CLASS	220		Seat/Door	OSB-FL - Multicontour backrest front left																																	
S-CLASS	220		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	220		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	220		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	220		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	220		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DCM-RR - Door control module rear right																				V													
S-CLASS	220		Seat/Door	DCM-RL - Door control module rear left																				V													
S-CLASS	220		Seat/Door	DCM-FR - Door control module front right																				V													
S-CLASS	220		Seat/Door	DCM-FL - Door control module front left																				V													
S-CLASS	220		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	220		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	220		Air Conditioning	AAC - Automatic air conditioning							V																										
S-CLASS	221		Drive	ME/CDI/CNG - Engine control unit											V	V			V										V	V		V	V	V			V
S-CLASS	221		Drive	ETC - Electronic transmission control																					V												
S-CLASS	221		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	221		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
S-CLASS	221		Drive	HSG - Hybrid control unit																V																	
S-CLASS	221		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	221		Drive	DTR - Distronic																																	
S-CLASS	221		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	221		Chassis	Suspension																																	
S-CLASS	221		Chassis	ES - Electrical power steering																																	
S-CLASS	221		Chassis	EFB - Electric parking brake																																	
S-CLASS	221		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	221		Body	WSS - Weight sensing system																																	
S-CLASS	221		Body	UCP - Upper control panel																																	
S-CLASS	221		Body	System diagnosis																																	
S-CLASS	221		Body	SG-DDW - DC/DC converter control unit																																	
S-CLASS	221		Body	SCM [MRM] - Steering column module																																	
S-CLASS	221		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	221		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	221		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	OCP - Overhead control panel																																	
S-CLASS	221		Body	Multifunction control unit																																	
S-CLASS	221		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	221		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	221		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	221		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	221		Body	CGW - Central gateway																																	
S-CLASS	221		Body	BNS/BMS - Battery sensor																																	
S-CLASS	221		Body	AHE - Trailer recognition																																	
S-CLASS	221		Body	AB - Airbag																																	
S-CLASS	221		Information	ZAN - Audio/COMAND display																																	
S-CLASS	221		Information	VCS - Voice control																																	
S-CLASS	221		Information	TV - TV tuner																																	
S-CLASS	221		Information	Tuner - Standard tuner																																	
S-CLASS	221		Information	SOUND - Sound system																																	
S-CLASS	221		Information	SGR - Radar sensors control unit																																	
S-CLASS	221		Information	MFK - Multifunction camera																																	
S-CLASS	221		Information	RFK - Backup camera																																	
S-CLASS	221		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
S-CLASS	221		Information	NSA - Night View Assist																																	
S-CLASS	221		Information	NBR-LF - Left front range radar																																	
S-CLASS	221		Information	NAV - Navigation module																																	
S-CLASS	221		Information	MIF/UCI - Media interface																																	
S-CLASS	221		Information	ICI - InCar Internet																																	
S-CLASS	221		Information	IC - Instrument cluster																																	
S-CLASS	221		Information	DVD player																																	
S-CLASS	221		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	221		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	221		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	221		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	221		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	221		Information	AVE-H - Rear audio video unit																																	
S-CLASS	221		Information	AUDIO/COMAND																																	
S-CLASS	221		Information	ASSYST PLUS - PLUS Active Service System																																	
S-CLASS	221		Information	ASSYST Active Service System																																	
S-CLASS	221		Seat/Door	TSG-MR - Right center door control unit																																	
S-CLASS	221		Seat/Door	TSG-ML - Left center door control unit																																	
S-CLASS	221		Seat/Door	TLC/GTO - Garage door opener																																	
S-CLASS	221		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	221		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
S-CLASS	221		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
S-CLASS	221		Seat/Door	HKS - Tailgate control																																	
S-CLASS	221		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	221		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	221		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	221		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	221		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	221		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	221		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	221		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	221		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	221		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	221		Air Conditioning	HBF - Rear control panel																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
S-CLASS	221		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	217		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	217		Drive	SG-EM - Power electronics																																	
S-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	217		Drive	DTR - Distronic																																	
S-CLASS	217		Drive	ISM - Intelligent servo module																																	
S-CLASS	217		Drive	PTCU - Common powertrain controller																																	
S-CLASS	217		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
S-CLASS	217		Drive	ETC - Electronic transmission control																																	
S-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	217		Chassis	ABS/ESP - Electronic stability program																V																	
S-CLASS	217		Chassis	ES - Electrical power steering																																	
S-CLASS	217		Chassis	Suspension																																	
S-CLASS	217		Chassis	EFB - Electric parking brake																																	
S-CLASS	217		Information	TPAD - Touchpad																																	
S-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	217		Information	360' - Camera																																	
S-CLASS	217		Information	SOUND - Sound system																																	
S-CLASS	217		Information	RFK - Backup camera																																	
S-CLASS	217		Information	SGR - Radar sensors control unit																																	
S-CLASS	217		Information	PTS - Parktronic system																																	
S-CLASS	217		Information	NSA - Night View Assist																																	
S-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	217		Information	NBR-RF - Right front range radar																																	
S-CLASS	217		Information	NBR-LF - Left front range radar																																	
S-CLASS	217		Information	MFK - Multifunction camera																																	
S-CLASS	217		Information	Head-up display																																	
S-CLASS	217		Information	AUDIO/COMAND																																	
S-CLASS	217		Information	ZAN - Audio/COMAND display																																	
S-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	217		Information	KAB - Camera cover																																	
S-CLASS	217		Information	IC - Instrument cluster																														V			
S-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	217		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
S-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	AB - Airbag																																	
S-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	217		Body	BNS/BMS - Battery sensor																																	
S-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	217		Seat/Door	HKS - Tailgate control																																	
S-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
S-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	222		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	222		Drive	SG-EM - Power electronics																																	
S-CLASS	222		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	222		Drive	DTR - Distronic																																	
S-CLASS	222		Drive	ISM - Intelligent servo module																																	
S-CLASS	222		Drive	PTCU - Common powertrain controller																																	
S-CLASS	222		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
S-CLASS	222		Drive	ETC - Electronic transmission control																																	
S-CLASS	222		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	222		Chassis	ES - Electrical power steering																																	
S-CLASS	222		Chassis	ABS/ESP - Electronic stability program																V																	
S-CLASS	222		Chassis	Suspension																																	
S-CLASS	222		Chassis	EFB - Electric parking brake																																	
S-CLASS	222		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
S-CLASS	222		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	222		Information	360' - Camera																																	
S-CLASS	222		Information	Sound generator for exhaust system																																	
S-CLASS	222		Information	SOUND - Sound system																																	
S-CLASS	222		Information	RFK - Backup camera																																	
S-CLASS	222		Information	SGR - Radar sensors control unit																																	
S-CLASS	222		Information	PTS - Parktronic system																																	
S-CLASS	222		Information	NSA - Night View Assist																																	
S-CLASS	222		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	222		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	222		Information	NBR-RF - Right front range radar																																	
S-CLASS	222		Information	NBR-LF - Left front range radar																																	
S-CLASS	222		Information	MFK - Multifunction camera																																	
S-CLASS	222		Information	Head-up display																																	
S-CLASS	222		Information	AUDIO/COMAND																																	
S-CLASS	222		Information	AVE-H - Rear audio video unit																																	
S-CLASS	222		Information	ZAN - Audio/COMAND display																																	
S-CLASS	222		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	222		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	222		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	222		Information	KAB - Camera cover																																	
S-CLASS	222		Information	IC - Instrument cluster																														V			
S-CLASS	222		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	222		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	222		Body	AHE - Trailer recognition																																	
S-CLASS	222		Body	SCM [MRM] - Steering column module																																	
S-CLASS	222		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	AB - Airbag																																	
S-CLASS	222		Body	Multifunction control unit																																	
S-CLASS	222		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	222		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	222		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	222		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
S-CLASS	222		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	222		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
S-CLASS	222		Body	BNS/BMS - Battery sensor																																	
S-CLASS	222		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	222		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	222		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	222		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	222		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
S-CLASS	222		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
S-CLASS	222		Seat/Door	HKS - Tailgate control																																	
S-CLASS	222		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	222		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	222		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	222		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	222		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	222		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	222		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	222		Air Conditioning	AAC - Automatic air conditioning																																	
G-CLASS	461 - 38P Connector		Drive	EVE																																	
G-CLASS	461 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 38P Connector		Information	IC - Instrument cluster																																	
G-CLASS	461 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	461 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
G-CLASS	461 - 16P Connector		Drive	ETC - Electronic transmission control																					V												
G-CLASS	461 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	461 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	461 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																	V																
G-CLASS	461 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	461 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	461 - 16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
G-CLASS	461 - 16P Connector		Body	CGW - Central gateway																																	
G-CLASS	461 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 16P Connector		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
G-CLASS	461 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	461 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	461 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 38P Connector		Drive	ME/CDI/CNG - Engine control unit																																	
G-CLASS	463 - 38P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	463 - 38P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 38P Connector		Drive	CC - Cruise control																																	
G-CLASS	463 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	463 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 38P Connector		Information	IC - Instrument cluster								V	V				V																			V	
G-CLASS	463 - 38P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 38P Connector		Information	APS - Auto pilot system																																	
G-CLASS	463 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit											V	V			V									V	V		V	V	V				V
G-CLASS	463 - 16P Connector		Drive	ETC - Electronic transmission control																					V												
G-CLASS	463 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	463 - 16P Connector		Drive	SCR - Selective catalytic reduction																																	
G-CLASS	463 - 16P Connector		Drive	ISM - Intelligent servo module																																	
G-CLASS	463 - 16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
G-CLASS	463 - 16P Connector		Drive	DTR - Distronic																																	
G-CLASS	463 - 16P Connector		Drive	DSI - Direct select interface																																	
G-CLASS	463 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																	V						V										
G-CLASS	463 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	463 - 16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
G-CLASS	463 - 16P Connector		Body	UCP - Upper control panel																																	
G-CLASS	463 - 16P Connector		Body	SCM [MRM] - Steering column module																																	
G-CLASS	463 - 16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
G-CLASS	463 - 16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																								V									
G-CLASS	463 - 16P Connector		Body	OCP - Overhead control panel	V																																
G-CLASS	463 - 16P Connector		Body	Multifunction control unit																																	
G-CLASS	463 - 16P Connector		Body	HSW/LRH - Steering wheel heater																																	
G-CLASS	463 - 16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
G-CLASS	463 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	463 - 16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
G-CLASS	463 - 16P Connector		Body	AHE - Trailer recognition																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
G-CLASS	463 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 16P Connector		Information	ZAN - Audio/COMAND display																																	
G-CLASS	463 - 16P Connector		Information	TV - TV tuner																																	
G-CLASS	463 - 16P Connector		Information	SOUND - Sound system																																	
G-CLASS	463 - 16P Connector		Information	PTS - Parktronic system																																	
G-CLASS	463 - 16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NAV - Navigation module																																	
G-CLASS	463 - 16P Connector		Information	MIF/UCI - Media interface																																	
G-CLASS	463 - 16P Connector		Information	IC - Instrument cluster									V	V			V																		V	V	
G-CLASS	463 - 16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
G-CLASS	463 - 16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
G-CLASS	463 - 16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
G-CLASS	463 - 16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
G-CLASS	463 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	463 - 16P Connector		Seat/Door	HS - Seat heater																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger		V	V	V	V	V																											
G-CLASS	463 - 16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver		V	V	V	V	V																											
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RR - Door control module rear right																				V													
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RL - Door control module rear left																				V													
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FR - Door control module front right																				V													
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FL - Door control module front left																				V													
G-CLASS	463 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Air Conditioning	AAC - Automatic air conditioning							V												V														
GLA-CLASS	156		Drive	VG - Transfer case																																	
GLA-CLASS	156		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
GLA-CLASS	156		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLA-CLASS	156		Drive	ETC - Electronic transmission control																																	
GLA-CLASS	156		Drive	DTR - Distronic																																	
GLA-CLASS	156		Drive	DSI - Direct select interface																																	
GLA-CLASS	156		Drive	PTCU - Common powertrain controller																																	
GLA-CLASS	156		Chassis	ABS/ESP - Electronic stability program																																	
GLA-CLASS	156		Chassis	ES - Electrical power steering																																	
GLA-CLASS	156		Chassis	EFB - Electric parking brake																																	
GLA-CLASS	156		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
GLA-CLASS	156		Body	SG-AWF - Collision prevention assist																																	
GLA-CLASS	156		Body	SCM [MRM] - Steering column module																																	
GLA-CLASS	156		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLA-CLASS	156		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	Multifunction control unit																																	
GLA-CLASS	156		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLA-CLASS	156		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLA-CLASS	156		Body	EZS/EIS - Electronic ignition lock																																	
GLA-CLASS	156		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLA-CLASS	156		Body	AHE - Trailer recognition																																	
GLA-CLASS	156		Body	AB - Airbag																																	
GLA-CLASS	156		Information	Head-up display																																	
GLA-CLASS	156		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLA-CLASS	156		Information	KAB - Camera cover																																	
GLA-CLASS	156		Information	ZAN - Audio/COMAND display																																	
GLA-CLASS	156		Information	TV - TV tuner																																	
GLA-CLASS	156		Information	SOUND - Sound system																																	
GLA-CLASS	156		Information	RFK - Backup camera																																	
GLA-CLASS	156		Information	MFK - Multifunction camera																																	
GLA-CLASS	156		Information	PTS - Parktronic system																																	
GLA-CLASS	156		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLA-CLASS	156		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLA-CLASS	156		Information	NAV - Navigation module																																	
GLA-CLASS	156		Information	MIF/UCI - Media interface																																	
GLA-CLASS	156		Information	IC - Instrument cluster																														V			
GLA-CLASS	156		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLA-CLASS	156		Information	DAB/SDAR - Digital/Satellite radio																																	
GLA-CLASS	156		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLA-CLASS	156		Information	AUDIO/COMAND																																	
GLA-CLASS	156		Seat/Door	HKS - Tailgate control																																	
GLA-CLASS	156		Seat/Door	PSD/MSC - Sliding roof control																																	
GLA-CLASS	156		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLA-CLASS	156		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLA-CLASS	156		Seat/Door	DCM-FR - Door control module front right																																	
GLA-CLASS	156		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
GLA-CLASS	156		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLA-CLASS	156		Air Conditioning	AAC - Automatic air conditioning																			V														
GLK-CLASS	204		Drive	ME/CDI/CNG - Engine control unit											V	V			V										V	V		V	V	V			V
GLK-CLASS	204		Drive	ETC - Electronic transmission control																					V												
GLK-CLASS	204		Drive	ESM - Electronic selector module																																	
GLK-CLASS	204		Drive	SCR - Selective catalytic reduction																																	
GLK-CLASS	204		Drive	PTCU - Common powertrain controller																																	
GLK-CLASS	204		Drive	ISM - Intelligent servo module																																	
GLK-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
GLK-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLK-CLASS	204		Drive	DTR - Distronic																																	
GLK-CLASS	204		Drive	AMG DRIVE UNIT																																	
GLK-CLASS	204		Chassis	ABS/ESP - Electronic stability program																																	
GLK-CLASS	204		Chassis	Suspension																																	
GLK-CLASS	204		Chassis	ES - Electrical power steering																																	
GLK-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
GLK-CLASS	204		Body	WSS - Weight sensing system																																	
GLK-CLASS	204		Body	SCM [MRM] - Steering column module																																	
GLK-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLK-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLK-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	OCP - Overhead control panel																																	
GLK-CLASS	204		Body	Multifunction control unit																																	
GLK-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLK-CLASS	204		Body	Headlamp-R - Headlamp control unit																																	
GLK-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLK-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	
GLK-CLASS	204		Body	CGW - Central gateway																																	
GLK-CLASS	204		Body	AHE - Trailer recognition																																	
GLK-CLASS	204		Body	AB - Airbag																																	
GLK-CLASS	204		Information	Head-up display																																	
GLK-CLASS	204		Information	AVE-H - Rear audio video unit																																	
GLK-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLK-CLASS	204		Information	ZAN - Audio/COMAND display																																	
GLK-CLASS	204		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
GLK-CLASS	204		Information	Sound generator for exhaust system																																	
GLK-CLASS	204		Information	SOUND - Sound system																																	
GLK-CLASS	204		Information	SGR - Radar sensors control unit																																	
GLK-CLASS	204		Information	360' - Camera																																	
GLK-CLASS	204		Information	MFK - Multifunction camera																																	
GLK-CLASS	204		Information	RFK - Backup camera																																	
GLK-CLASS	204		Information	PTS - Parktronic system																																	
GLK-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLK-CLASS	204		Information	NBR-RF - Right front range radar																																	
GLK-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLK-CLASS	204		Information	NBR-LF - Left front range radar																																	
GLK-CLASS	204		Information	NAV - Navigation module																																	
GLK-CLASS	204		Information	MIF/UCI - Media interface																																	
GLK-CLASS	204		Information	ICI - InCar Internet																																	
GLK-CLASS	204		Information	IC - Instrument cluster																														V			
GLK-CLASS	204		Information	DVD player																																	
GLK-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLK-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
GLK-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
GLK-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
GLK-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GLK-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLK-CLASS	204		Information	AUDIO/COMAND																																	
GLK-CLASS	204		Information	AMG Performance Media																																	
GLK-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
GLK-CLASS	204		Seat/Door	HKS - Tailgate control																																	
GLK-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLK-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLK-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
GLK-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
GLK-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
GLK-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
GLK-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLK-CLASS	204		Air Conditioning	AAC - Automatic air conditioning																			V														
GLC-CLASS	253		Drive	SCR - Selective catalytic reduction																																	
GLC-CLASS	253		Drive	SG-EM - Power electronics																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
GLC-CLASS	253		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLC-CLASS	253		Drive	DTR - Distronic																																	
GLC-CLASS	253		Drive	ISM - Intelligent servo module																																	
GLC-CLASS	253		Drive	PTCU - Common powertrain controller																																	
GLC-CLASS	253		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
GLC-CLASS	253		Drive	ETC - Electronic transmission control																																	
GLC-CLASS	253		Chassis	TPM - Tire pressure monitor																																	
GLC-CLASS	253		Chassis	AIRMATIC PLUS																																	
GLC-CLASS	253		Chassis	ES - Electrical power steering																																	
GLC-CLASS	253		Chassis	Suspension																																	
GLC-CLASS	253		Chassis	ABS/ESP - Electronic stability program																V																	
GLC-CLASS	253		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLC-CLASS	253		Body	AHE - Trailer recognition																																	
GLC-CLASS	253		Body	SCM [MRM] - Steering column module																																	
GLC-CLASS	253		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	AB - Airbag																																	
GLC-CLASS	253		Body	Multifunction control unit																																	
GLC-CLASS	253		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLC-CLASS	253		Body	Headlamp-R - Headlamp control unit																																	
GLC-CLASS	253		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLC-CLASS	253		Body	SG-AWF - Collision prevention assist																																	
GLC-CLASS	253		Body	EZS/EIS - Electronic ignition lock																																	
GLC-CLASS	253		Body	BNS/BMS - Battery sensor																																	
GLC-CLASS	253		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLC-CLASS	253		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLC-CLASS	253		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLC-CLASS	253		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLC-CLASS	253		Seat/Door	PSD/MSC - Sliding roof control																																	
GLC-CLASS	253		Seat/Door	HKS - Tailgate control																																	
GLC-CLASS	253		Seat/Door	DCM-RR - Door control module rear right																																	
GLC-CLASS	253		Seat/Door	DCM-RL - Door control module rear left																																	
GLC-CLASS	253		Seat/Door	DCM-FR - Door control module front right																																	
GLC-CLASS	253		Seat/Door	DCM-FL - Door control module front left																																	
GLC-CLASS	253		Information	TPAD - Touchpad																																	
GLC-CLASS	253		Information	DAB/SDAR - Digital/Satellite radio																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
GLC-CLASS	253		Information	360' - Camera																																	
GLC-CLASS	253		Information	Sound generator for exhaust system																																	
GLC-CLASS	253		Information	SOUND - Sound system																																	
GLC-CLASS	253		Information	RFK - Backup camera																																	
GLC-CLASS	253		Information	SGR - Radar sensors control unit																																	
GLC-CLASS	253		Information	PTS - Parktronic system																																	
GLC-CLASS	253		Information	NBR-RF - Right front range radar																																	
GLC-CLASS	253		Information	NBR-LF - Left front range radar																																	
GLC-CLASS	253		Information	MFK - Multifunction camera																																	
GLC-CLASS	253		Information	IC - Instrument cluster																														V			
GLC-CLASS	253		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLC-CLASS	253		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLC-CLASS	253		Information	Head-up display																																	
GLC-CLASS	253		Information	AUDIO/COMAND																																	
GLC-CLASS	253		Information	SG-MSND - Engine sound																																	
GLC-CLASS	253		Information	ZAN - Audio/COMAND display																																	
GLC-CLASS	253		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLC-CLASS	253		Information	KAB - Camera cover																																	
GLC-CLASS	253		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLC-CLASS	253		Information	AMG Performance Media																																	
GLC-CLASS	253		Air Conditioning	AAC - Automatic air conditioning																																	
GLE-CLASS	292		Drive	SCR - Selective catalytic reduction																																	
GLE-CLASS	292		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLE-CLASS	292		Drive	ISM - Intelligent servo module																																	
GLE-CLASS	292		Drive	DTR - Distronic																																	
GLE-CLASS	292		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
GLE-CLASS	292		Drive	ETC - Electronic transmission control																																	
GLE-CLASS	292		Chassis	TPM - Tire pressure monitor																																	
GLE-CLASS	292		Chassis	FWGW - Chassis gateway																																	
GLE-CLASS	292		Chassis	ABS/ESP - Electronic stability program																																	
GLE-CLASS	292		Chassis	ES - Electrical power steering																																	
GLE-CLASS	292		Chassis	EFB - Electric parking brake																																	
GLE-CLASS	292		Chassis	Suspension																																	
GLE-CLASS	292		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLE-CLASS	292		Body	AHE - Trailer recognition																																	
GLE-CLASS	292		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
GLE-CLASS	292		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLE-CLASS	292		Body	AB - Airbag																																	
GLE-CLASS	292		Body	Multifunction control unit																																	
GLE-CLASS	292		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLE-CLASS	292		Body	Headlamp-R - Headlamp control unit																																	
GLE-CLASS	292		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLE-CLASS	292		Body	SG-AWF - Collision prevention assist																																	
GLE-CLASS	292		Body	EZS/EIS - Electronic ignition lock																																	
GLE-CLASS	292		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLE-CLASS	292		Information	TPAD - Touchpad																																	
GLE-CLASS	292		Information	DAB/SDAR - Digital/Satellite radio																																	
GLE-CLASS	292		Information	360' - Camera																																	
GLE-CLASS	292		Information	SOUND - Sound system																																	
GLE-CLASS	292		Information	RFK - Backup camera																																	
GLE-CLASS	292		Information	SGR - Radar sensors control unit																																	
GLE-CLASS	292		Information	PTS - Parktronic system																																	
GLE-CLASS	292		Information	MFK - Multifunction camera																																	
GLE-CLASS	292		Information	NBR-RF - Right front range radar																																	
GLE-CLASS	292		Information	NBR-LF - Left front range radar																																	
GLE-CLASS	292		Information	IC - Instrument cluster																														V			
GLE-CLASS	292		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLE-CLASS	292		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLE-CLASS	292		Information	Head-up display																																	
GLE-CLASS	292		Information	AUDIO/COMAND																																	
GLE-CLASS	292		Information	AVE-H - Rear audio video unit																																	
GLE-CLASS	292		Information	DVD player																																	
GLE-CLASS	292		Information	SG-MSND - Engine sound																																	
GLE-CLASS	292		Information	ZAN - Audio/COMAND display																																	
GLE-CLASS	292		Information	D-FOR - Display in right rear passenger																																	
GLE-CLASS	292		Information	D-FOL - Display in left rear passenger																																	
GLE-CLASS	292		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLE-CLASS	292		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLE-CLASS	292		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLE-CLASS	292		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
GLE-CLASS	292		Seat/Door	PSD/MSC - Sliding roof control																																	
GLE-CLASS	292		Seat/Door	HKS - Tailgate control																																	
GLE-CLASS	292		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DCM-RR - Door control module rear right																																	
GLE-CLASS	292		Seat/Door	DCM-RL - Door control module rear left																																	
GLE-CLASS	292		Seat/Door	DCM-FR - Door control module front right																																	
GLE-CLASS	292		Seat/Door	DCM-FL - Door control module front left																																	
GLE-CLASS	292		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLE-CLASS	292		Air Conditioning	HBF - Rear control panel																																	
GLE-CLASS	292		Air Conditioning	AAC - Automatic air conditioning																			V														
GL-CLASS	164		Drive	ME/CDI/CNG - Engine control unit											V	V			V										V	V		V	V	V			V
GL-CLASS	164		Drive	ETC - Electronic transmission control																																	
GL-CLASS	164		Drive	VG - Transfer case																																	
GL-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
GL-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
GL-CLASS	164		Drive	SCR - Selective catalytic reduction																																	
GL-CLASS	164		Drive	ISM - Intelligent servo module																																	
GL-CLASS	164		Drive	HSG - Hybrid control unit																V																	
GL-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
GL-CLASS	164		Drive	DTR - Distronic																																	
GL-CLASS	164		Chassis	ABS/ESP - Electronic stability program																	V																
GL-CLASS	164		Chassis	Suspension																																	
GL-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
GL-CLASS	164		Chassis	ES - Electrical power steering																																	
GL-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	164		Body	WSS - Weight sensing system																																	
GL-CLASS	164		Body	UCP - Upper control panel																																	
GL-CLASS	164		Body	System diagnosis																																	
GL-CLASS	164		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																								V									
GL-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	OCP - Overhead control panel	V																																

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
GL-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
GL-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	164		Body	CGW - Central gateway																																	
GL-CLASS	164		Body	AB - Airbag																																	
GL-CLASS	164		Information	TV - TV tuner																																	
GL-CLASS	164		Information	SOUND - Sound system																																	
GL-CLASS	164		Information	RFK - Backup camera																																	
GL-CLASS	164		Information	PTS - Parktronic system																																	
GL-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	164		Information	NAV - Navigation module																																	
GL-CLASS	164		Information	MIF/UCI - Media interface																																	
GL-CLASS	164		Information	IC - Instrument cluster									V	V																							
GL-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GL-CLASS	164		Information	CM - Compass module																																	
GL-CLASS	164		Information	AVE-H - Rear audio video unit																																	
GL-CLASS	164		Information	AUDIO/COMAND																																	
GL-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
GL-CLASS	164		Information	ASSYST Active Service System									V																								
GL-CLASS	164		Information	AGW - Audio gateway																																	
GL-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
GL-CLASS	164		Seat/Door	HS - Seat heater																																	
GL-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger		V	V	V	V	V																											
GL-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver		V	V	V	V	V																											
GL-CLASS	164		Seat/Door	ERA - Electric fold down backrest system		V	V	V	V	V																											
GL-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DCM-FR - Door control module front right																				V													

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
GL-CLASS	164		Seat/Door	DCM-FL - Door control module front left																				V													
GL-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GL-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
GL-CLASS	164		Air Conditioning	AAC - Automatic air conditioning							V																										
GL-CLASS	166		Drive	SG-EM - Power electronics																																	
GL-CLASS	166		Drive	PTCU - Common powertrain controller																																	
GL-CLASS	166		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
GL-CLASS	166		Drive	ETC - Electronic transmission control																																	
GL-CLASS	166		Drive	VG - Transfer case																																	
GL-CLASS	166		Drive	SCR - Selective catalytic reduction																																	
GL-CLASS	166		Drive	ISM - Intelligent servo module																																	
GL-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	166		Drive	DTR - Distronic																																	
GL-CLASS	166		Chassis	ABS/ESP - Electronic stability program																																	
GL-CLASS	166		Chassis	Suspension																																	
GL-CLASS	166		Chassis	ES - Electrical power steering																																	
GL-CLASS	166		Chassis	EFB - Electric parking brake																																	
GL-CLASS	166		Chassis	FWGW - Chassis gateway																																	
GL-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
GL-CLASS	166		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GL-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	Multifunction control unit																																	
GL-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GL-CLASS	166		Body	AHE - Trailer recognition																																	
GL-CLASS	166		Body	AB - Airbag																																	
GL-CLASS	166		Information	Sound generator for exhaust system																																	
GL-CLASS	166		Information	Head-up display																																	
GL-CLASS	166		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
GL-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GL-CLASS	166		Information	ZAN - Audio/COMAND display																																	
GL-CLASS	166		Information	TV - TV tuner																																	
GL-CLASS	166		Information	SOUND - Sound system																																	
GL-CLASS	166		Information	SGR - Radar sensors control unit																																	
GL-CLASS	166		Information	360' - Camera																																	
GL-CLASS	166		Information	RFK - Backup camera																																	
GL-CLASS	166		Information	MFK - Multifunction camera																																	
GL-CLASS	166		Information	PTS - Parktronic system																																	
GL-CLASS	166		Information	NSA - Night View Assist																																	
GL-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	166		Information	NBR-RF - Right front range radar																																	
GL-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	166		Information	NBR-LF - Left front range radar																																	
GL-CLASS	166		Information	NAV - Navigation module																																	
GL-CLASS	166		Information	MIF/UCI - Media interface																																	
GL-CLASS	166		Information	IC - Instrument cluster																															V		
GL-CLASS	166		Information	DVD player																																	
GL-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GL-CLASS	166		Information	AUDIO/COMAND																																	
GL-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
GL-CLASS	166		Seat/Door	HKS - Tailgate control																																	
GL-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
GL-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
GL-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
GL-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
GL-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
GL-CLASS	166		Air Conditioning	AAC - Automatic air conditioning																			V														
M-CLASS	163		Drive	ME/CDI/CNG - Engine control unit																																	
M-CLASS	163		Drive	ETC - Electronic transmission control																					V												
M-CLASS	163		Drive	ESM - Electronic selector module																																	
M-CLASS	163		Drive	VG - Transfer case																																	
M-CLASS	163		Chassis	ABS/ESP - Electronic stability program																	V						V										
M-CLASS	163		Chassis	VP - Vacuum pump brake booster																																	
M-CLASS	163		Chassis	BAS - Brake assist																																	
M-CLASS	163		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	163		Body	AB - Airbag																																	
M-CLASS	163		Body	AAM - All activity module																																	
M-CLASS	163		Information	PTS - Parktronic system																																	
M-CLASS	163		Information	IC - Instrument cluster								V					V																				
M-CLASS	163		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	163		Information	AUDIO/COMAND																																	
M-CLASS	163		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	163		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Drive	ME/CDI/CNG - Engine control unit											V	V			V										V	V		V	V	V			V
M-CLASS	164		Drive	ETC - Electronic transmission control																																	
M-CLASS	164		Drive	VG - Transfer case																																	
M-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
M-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
M-CLASS	164		Drive	SCR - Selective catalytic reduction																																	
M-CLASS	164		Drive	ISM - Intelligent servo module																																	
M-CLASS	164		Drive	HSG - Hybrid control unit																V																	
M-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
M-CLASS	164		Drive	DTR - Distronic																																	
M-CLASS	164		Chassis	ABS/ESP - Electronic stability program																	V																
M-CLASS	164		Chassis	Suspension																																	
M-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
M-CLASS	164		Chassis	ES - Electrical power steering																																	
M-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	164		Body	WSS - Weight sensing system																																	
M-CLASS	164		Body	UCP - Upper control panel																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
M-CLASS	164		Body	System diagnosis																																	
M-CLASS	164		Body	SCM [MRM] - Steering column module																																	
M-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																							V										
M-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	OCP - Overhead control panel	V																																
M-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
M-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	164		Body	CGW - Central gateway																																	
M-CLASS	164		Body	AB - Airbag																																	
M-CLASS	164		Information	TV - TV tuner																																	
M-CLASS	164		Information	SOUND - Sound system																																	
M-CLASS	164		Information	RFK - Backup camera																																	
M-CLASS	164		Information	PTS - Parktronic system																																	
M-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	164		Information	NAV - Navigation module																																	
M-CLASS	164		Information	MIF/UCI - Media interface																																	
M-CLASS	164		Information	IC - Instrument cluster									V	V																							
M-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
M-CLASS	164		Information	CM - Compass module																																	
M-CLASS	164		Information	AVE-H - Rear audio video unit																																	
M-CLASS	164		Information	AUDIO/COMAND																																	
M-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
M-CLASS	164		Information	ASSYST Active Service System									V																								
M-CLASS	164		Information	AGW - Audio gateway																																	
M-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
M-CLASS	164		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
M-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger		V	V	V	V	V																											
M-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver		V	V	V	V	V																											
M-CLASS	164		Seat/Door	ERA - Electric fold down backrest system		V	V	V	V	V																											
M-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DCM-FR - Door control module front right																				V													
M-CLASS	164		Seat/Door	DCM-FL - Door control module front left																				V													
M-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
M-CLASS	164		Air Conditioning	AAC - Automatic air conditioning							V																										
M-CLASS	166		Drive	SG-EM - Power electronics																																	
M-CLASS	166		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
M-CLASS	166		Drive	ETC - Electronic transmission control																																	
M-CLASS	166		Drive	VG - Transfer case																																	
M-CLASS	166		Drive	SCR - Selective catalytic reduction																																	
M-CLASS	166		Drive	PTCU - Common powertrain controller																																	
M-CLASS	166		Drive	ISM - Intelligent servo module																																	
M-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	166		Drive	DTR - Distronic																																	
M-CLASS	166		Chassis	ABS/ESP - Electronic stability program																																	
M-CLASS	166		Chassis	Suspension																																	
M-CLASS	166		Chassis	ES - Electrical power steering																																	
M-CLASS	166		Chassis	EFB - Electric parking brake																																	
M-CLASS	166		Chassis	FWGW - Chassis gateway																																	
M-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
M-CLASS	166		Body	SCM [MRM] - Steering column module																																	
M-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
M-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	Multifunction control unit																																	
M-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
M-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
M-CLASS	166		Body	AHE - Trailer recognition																																	
M-CLASS	166		Body	AB - Airbag																																	
M-CLASS	166		Information	Sound generator for exhaust system																																	
M-CLASS	166		Information	Head-up display																																	
M-CLASS	166		Information	AVE-H - Rear audio video unit																																	
M-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
M-CLASS	166		Information	ZAN - Audio/COMAND display																																	
M-CLASS	166		Information	TV - TV tuner																																	
M-CLASS	166		Information	SOUND - Sound system																																	
M-CLASS	166		Information	SGR - Radar sensors control unit																																	
M-CLASS	166		Information	360' - Camera																																	
M-CLASS	166		Information	RFK - Backup camera																																	
M-CLASS	166		Information	MFK - Multifunction camera																																	
M-CLASS	166		Information	PTS - Parktronic system																																	
M-CLASS	166		Information	NSA - Night View Assist																																	
M-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	166		Information	NBR-RF - Right front range radar																																	
M-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	166		Information	NBR-LF - Left front range radar																																	
M-CLASS	166		Information	NAV - Navigation module																																	
M-CLASS	166		Information	MIF/UCI - Media interface																																	
M-CLASS	166		Information	IC - Instrument cluster																														V			
M-CLASS	166		Information	DVD player																																	
M-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
M-CLASS	166		Information	AUDIO/COMAND																																	
M-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
M-CLASS	166		Seat/Door	HKS - Tailgate control																																	
M-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
M-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
M-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
M-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
M-CLASS	166		Air Conditioning	AAC - Automatic air conditioning																			V														
R-CLASS	251		Drive	ME/CDI/CNG - Engine control unit											V	V			V										V	V		V	V	V			V
R-CLASS	251		Drive	ETC - Electronic transmission control																																	
R-CLASS	251		Drive	SCR - Selective catalytic reduction																																	
R-CLASS	251		Drive	ISM - Intelligent servo module																																	
R-CLASS	251		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
R-CLASS	251		Drive	DTR - Distronic																																	
R-CLASS	251		Chassis	ABS/ESP - Electronic stability program																	V																
R-CLASS	251		Chassis	Suspension																																	
R-CLASS	251		Chassis	ES - Electrical power steering																																	
R-CLASS	251		Chassis	TPM - Tire pressure monitor																																	
R-CLASS	251		Body	WSS - Weight sensing system																																	
R-CLASS	251		Body	UCP - Upper control panel																																	
R-CLASS	251		Body	System diagnosis																																	
R-CLASS	251		Body	SCM [MRM] - Steering column module																																	
R-CLASS	251		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
R-CLASS	251		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																							V										
R-CLASS	251		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	OCP - Overhead control panel	V																																
R-CLASS	251		Body	LCP/HBF - Lower/Rear control panel																																	
R-CLASS	251		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
R-CLASS	251		Body	Headlamp-R - Headlamp control unit																																	
R-CLASS	251		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
R-CLASS	251		Body	EZS/EIS - Electronic ignition lock																																	
R-CLASS	251		Body	CGW - Central gateway																																	
R-CLASS	251		Body	AB - Airbag																																	
R-CLASS	251		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
R-CLASS	251		Information	SOUND - Sound system																																	
R-CLASS	251		Information	RFK - Backup camera																																	
R-CLASS	251		Information	PTS - Parktronic system																																	
R-CLASS	251		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
R-CLASS	251		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
R-CLASS	251		Information	NAV - Navigation module																																	
R-CLASS	251		Information	MIF/UCI - Media interface																																	
R-CLASS	251		Information	IC - Instrument cluster									V	V																							
R-CLASS	251		Information	DTA - Mbrace or TELEAID/GPS Box																																	
R-CLASS	251		Information	D-FOR - Display in right rear passenger																																	
R-CLASS	251		Information	D-FOL - Display in left rear passenger																																	
R-CLASS	251		Information	DAB/SDAR - Digital/Satellite radio																																	
R-CLASS	251		Information	CTEL/TEL - Cellular/Mobile telephone																																	
R-CLASS	251		Information	CM - Compass module																																	
R-CLASS	251		Information	AVE-H - Rear audio video unit																																	
R-CLASS	251		Information	AUDIO/COMAND																																	
R-CLASS	251		Information	ASSYST PLUS - PLUS Active Service System																																	
R-CLASS	251		Information	ASSYST Active Service System									V																								
R-CLASS	251		Information	AGW - Audio gateway																																	
R-CLASS	251		Seat/Door	REDC/RWT - Rear end door control module																																	
R-CLASS	251		Seat/Door	HS - Seat heater																																	
R-CLASS	251		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger		V	V	V	V	V																											
R-CLASS	251		Seat/Door	ESA Driver - Electric seat adjustment Driver		V	V	V	V	V																											
R-CLASS	251		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
R-CLASS	251		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DCM-FR - Door control module front right																				V													
R-CLASS	251		Seat/Door	DCM-FL - Door control module front left																				V													
R-CLASS	251		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
R-CLASS	251		Air Conditioning	AAC - Automatic air conditioning							V																										
CLA-CLASS	117		Drive	VG - Transfer case																																	
CLA-CLASS	117		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
CLA-CLASS	117		Drive	ETC - Electronic transmission control																																	
CLA-CLASS	117		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLA-CLASS	117		Drive	DTR - Distronic																																	
CLA-CLASS	117		Drive	DSI - Direct select interface																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
CLA-CLASS	117		Drive	PTCU - Common powertrain controller																																	
CLA-CLASS	117		Chassis	ABS/ESP - Electronic stability program																																	
CLA-CLASS	117		Chassis	ES - Electrical power steering																																	
CLA-CLASS	117		Chassis	EFB - Electric parking brake																																	
CLA-CLASS	117		Chassis	TPM - Tire pressure monitor																																	
CLA-CLASS	117		Body	SG-AWF - Collision prevention assist																																	
CLA-CLASS	117		Body	SCM [MRM] - Steering column module																																	
CLA-CLASS	117		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLA-CLASS	117		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	Multifunction control unit																																	
CLA-CLASS	117		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLA-CLASS	117		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLA-CLASS	117		Body	EZS/EIS - Electronic ignition lock																																	
CLA-CLASS	117		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CLA-CLASS	117		Body	AHE - Trailer recognition																																	
CLA-CLASS	117		Body	AB - Airbag																																	
CLA-CLASS	117		Information	Head-up display																																	
CLA-CLASS	117		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLA-CLASS	117		Information	KAB - Camera cover																																	
CLA-CLASS	117		Information	ZAN - Audio/COMAND display																																	
CLA-CLASS	117		Information	TV - TV tuner																																	
CLA-CLASS	117		Information	SOUND - Sound system																																	
CLA-CLASS	117		Information	RFK - Backup camera																																	
CLA-CLASS	117		Information	MFK - Multifunction camera																																	
CLA-CLASS	117		Information	PTS - Parktronic system																																	
CLA-CLASS	117		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLA-CLASS	117		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLA-CLASS	117		Information	NAV - Navigation module																																	
CLA-CLASS	117		Information	MIF/UCI - Media interface																																	
CLA-CLASS	117		Information	IC - Instrument cluster																														V			
CLA-CLASS	117		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLA-CLASS	117		Information	DAB/SDAR - Digital/Satellite radio																																	
CLA-CLASS	117		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLA-CLASS	117		Information	AUDIO/COMAND																																	
CLA-CLASS	117		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
CLA-CLASS	117		Seat/Door	PSD/MSC - Sliding roof control																																	
CLA-CLASS	117		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLA-CLASS	117		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLA-CLASS	117		Seat/Door	DCM-FR - Door control module front right																																	
CLA-CLASS	117		Seat/Door	DCM-FL - Door control module front left																																	
CLA-CLASS	117		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLA-CLASS	117		Air Conditioning	AAC - Automatic air conditioning																			V														
CLK-CLASS	208		Drive	ME/CDI/CNG - Engine control unit																										V							
CLK-CLASS	208		Drive	ETC - Electronic transmission control																					V												
CLK-CLASS	208		Drive	ESM - Electronic selector module																																	
CLK-CLASS	208		Chassis	PSE - Pneumatic system equipment																																	
CLK-CLASS	208		Chassis	ABS/ESP - Electronic stability program																							V										
CLK-CLASS	208		Chassis	VP - Vacuum pump brake booster																																	
CLK-CLASS	208		Chassis	BAS - Brake assist																																	
CLK-CLASS	208		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	208		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	208		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	208		Body	OCP - Overhead control panel																																	
CLK-CLASS	208		Body	AB - Airbag																																	
CLK-CLASS	208		Information	TV - TV tuner																																	
CLK-CLASS	208		Information	PTS - Parktronic system																																	
CLK-CLASS	208		Information	NAV - Navigation module																																	
CLK-CLASS	208		Information	IC - Instrument cluster								V	V				V																			V	
CLK-CLASS	208		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	208		Information	AUDIO/COMAND																																	
CLK-CLASS	208		Information	APS - Auto pilot system																																	
CLK-CLASS	208		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	208		Air Conditioning	AAC - Automatic air conditioning							V																										
CLK-CLASS	208		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	208		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	208		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	208		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Drive	ME/CDI/CNG - Engine control unit															V											V		V					V
CLK-CLASS	209		Drive	ETC - Electronic transmission control																					V												
CLK-CLASS	209		Drive	ESM - Electronic selector module																																	
CLK-CLASS	209		Drive	DTR - Distronic																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
CLK-CLASS	209		Chassis	ABS/ESP - Electronic stability program																	V																
CLK-CLASS	209		Chassis	TPM - Tire pressure monitor																																	
CLK-CLASS	209		Body	WSS - Weight sensing system																																	
CLK-CLASS	209		Body	UCP - Upper control panel																																	
CLK-CLASS	209		Body	SCM [MRM] - Steering column module																																	
CLK-CLASS	209		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLK-CLASS	209		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																							V										
CLK-CLASS	209		Body	RCM - Rear control module																																	
CLK-CLASS	209		Body	OCP - Overhead control panel	V																																
CLK-CLASS	209		Body	Multifunction control unit																																	
CLK-CLASS	209		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	209		Body	Headlamp-R - Headlamp control unit																																	
CLK-CLASS	209		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLK-CLASS	209		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	209		Body	BNS/BMS - Battery sensor																																	
CLK-CLASS	209		Body	AHE - Trailer recognition																																	
CLK-CLASS	209		Body	AB - Airbag																																	
CLK-CLASS	209		Information	TV - TV tuner																																	
CLK-CLASS	209		Information	PTS - Parktronic system																																	
CLK-CLASS	209		Information	NAV - Navigation module																																	
CLK-CLASS	209		Information	IC - Instrument cluster									V	V			V																			V	
CLK-CLASS	209		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	209		Information	AUDIO/COMAND																																	
CLK-CLASS	209		Information	AGW - Audio gateway																																	
CLK-CLASS	209		Seat/Door	RVC/VDS - Convertible roof control																																	
CLK-CLASS	209		Seat/Door	REDC/RWT - Rear end door control module																																	
CLK-CLASS	209		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger		V	V	V	V	V																											
CLK-CLASS	209		Seat/Door	ESA Driver - Electric seat adjustment Driver		V	V	V	V	V																											
CLK-CLASS	209		Seat/Door	DCM-FR - Door control module front right																				V													
CLK-CLASS	209		Seat/Door	DCM-FL - Door control module front left																				V													
CLK-CLASS	209		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	209		Air Conditioning	AAC - Automatic air conditioning							V																										
CLS-CLASS	219		Drive	ME/CDI/CNG - Engine control unit															V										V		V						V
CLS-CLASS	219		Drive	ETC - Electronic transmission control																					V												
CLS-CLASS	219		Drive	ESM - Electronic selector module																																	
CLS-CLASS	219		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
CLS-CLASS	219		Drive	DTR - Distronic																																	
CLS-CLASS	219		Chassis	ABS/ESP - Electronic stability program																	V																
CLS-CLASS	219		Chassis	Suspension																																	
CLS-CLASS	219		Chassis	SBC - Sensotronic Brake Control																																	
CLS-CLASS	219		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	219		Body	WSS - Weight sensing system																																	
CLS-CLASS	219		Body	UCP - Upper control panel																																	
CLS-CLASS	219		Body	System diagnosis																																	
CLS-CLASS	219		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	219		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	219		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CLS-CLASS	219		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																							V										
CLS-CLASS	219		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	OCP - Overhead control panel	V																																
CLS-CLASS	219		Body	LCP/HBF - Lower/Rear control panel																																	
CLS-CLASS	219		Body	LAE [LAA] - Loading floor automatically extendable																																	
CLS-CLASS	219		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	219		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	219		Body	CGW - Central gateway																																	
CLS-CLASS	219		Body	BNS/BMS - Battery sensor																																	
CLS-CLASS	219		Body	AB - Airbag																																	
CLS-CLASS	219		Information	TV - TV tuner																																	
CLS-CLASS	219		Information	SOUND - Sound system																																	
CLS-CLASS	219		Information	PTS - Parktronic system																																	
CLS-CLASS	219		Information	MIF/UCI - Media interface																																	
CLS-CLASS	219		Information	IC - Instrument cluster									V	V																							
CLS-CLASS	219		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	219		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	219		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	219		Information	AUDIO/COMAND																																	
CLS-CLASS	219		Information	ASSYST PLUS - PLUS Active Service System																																	
CLS-CLASS	219		Information	ASSYST Active Service System									V																								
CLS-CLASS	219		Information	AGW - Audio gateway																																	
CLS-CLASS	219		Seat/Door	REDC/RWT - Rear end door control module																																	
CLS-CLASS	219		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
CLS-CLASS	219		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger		V	V	V	V	V																											
CLS-CLASS	219		Seat/Door	ESA Driver - Electric seat adjustment Driver		V	V	V	V	V																											
CLS-CLASS	219		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	219		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DCM-RR - Door control module rear right																				V													
CLS-CLASS	219		Seat/Door	DCM-RL - Door control module rear left																				V													
CLS-CLASS	219		Seat/Door	DCM-FR - Door control module front right																				V													
CLS-CLASS	219		Seat/Door	DCM-FL - Door control module front left																				V													
CLS-CLASS	219		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	219		Air Conditioning	AAC - Automatic air conditioning							V																										
CLS-CLASS	218		Drive	ME/CDI/CNG - Engine control unit											V	V			V										V	V		V	V	V			V
CLS-CLASS	218		Drive	ETC - Electronic transmission control																																	
CLS-CLASS	218		Drive	ESM - Electronic selector module																																	
CLS-CLASS	218		Drive	SCR - Selective catalytic reduction																																	
CLS-CLASS	218		Drive	ISM - Intelligent servo module																																	
CLS-CLASS	218		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLS-CLASS	218		Drive	DTR - Distronic																																	
CLS-CLASS	218		Drive	DSI - Direct select interface																																	
CLS-CLASS	218		Drive	AMG DRIVE UNIT																																	
CLS-CLASS	218		Chassis	ABS/ESP - Electronic stability program																																	
CLS-CLASS	218		Chassis	Suspension																																	
CLS-CLASS	218		Chassis	ES - Electrical power steering																																	
CLS-CLASS	218		Chassis	FWGW - Chassis gateway																																	
CLS-CLASS	218		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	218		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
CLS-CLASS	218		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
CLS-CLASS	218		Body	WSS - Weight sensing system																																	
CLS-CLASS	218		Body	SG-AWF - Collision prevention assist																																	
CLS-CLASS	218		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	218		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	218		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLS-CLASS	218		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	OCP - Overhead control panel																																	
CLS-CLASS	218		Body	Multifunction control unit																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
CLS-CLASS	218		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLS-CLASS	218		Body	HSW/LRH - Steering wheel heater																																	
CLS-CLASS	218		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
CLS-CLASS	218		Body	Headlamp-R - Headlamp control unit																																	
CLS-CLASS	218		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	218		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	218		Body	CGW - Central gateway																																	
CLS-CLASS	218		Body	AHE - Trailer recognition																																	
CLS-CLASS	218		Body	AB - Airbag																																	
CLS-CLASS	218		Information	360' - Camera																																	
CLS-CLASS	218		Information	AVE-H - Rear audio video unit																																	
CLS-CLASS	218		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLS-CLASS	218		Information	ZAN - Audio/COMAND display																																	
CLS-CLASS	218		Information	TV - TV tuner																																	
CLS-CLASS	218		Information	SOUND - Sound system																																	
CLS-CLASS	218		Information	SGR - Radar sensors control unit																																	
CLS-CLASS	218		Information	MFK - Multifunction camera																																	
CLS-CLASS	218		Information	RFK - Backup camera																																	
CLS-CLASS	218		Information	PTS - Parktronic system																																	
CLS-CLASS	218		Information	NSA - Night View Assist																																	
CLS-CLASS	218		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLS-CLASS	218		Information	NBR-RF - Right front range radar																																	
CLS-CLASS	218		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLS-CLASS	218		Information	NBR-LF - Left front range radar																																	
CLS-CLASS	218		Information	NAV - Navigation module																																	
CLS-CLASS	218		Information	MIF/UCI - Media interface																																	
CLS-CLASS	218		Information	ICI - InCar Internet																																	
CLS-CLASS	218		Information	IC - Instrument cluster																														V			
CLS-CLASS	218		Information	DVD player																																	
CLS-CLASS	218		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	218		Information	D-FOR - Display in right rear passenger																																	
CLS-CLASS	218		Information	D-FOL - Display in left rear passenger																																	
CLS-CLASS	218		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	218		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	218		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLS-CLASS	218		Information	AUDIO/COMAND																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
CLS-CLASS	218		Seat/Door	PSD/MSC - Sliding roof control																																	
CLS-CLASS	218		Seat/Door	HKS - Tailgate control																																	
CLS-CLASS	218		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	218		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	218		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	218		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	218		Seat/Door	DCM-RL - Door control module rear left																																	
CLS-CLASS	218		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	218		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	218		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	218		Air Conditioning	AAC - Automatic air conditioning																			V														
CL-CLASS	215		Drive	ME/CDI/CNG - Engine control unit																																	
CL-CLASS	215		Drive	ETC - Electronic transmission control																					V												
CL-CLASS	215		Drive	ESM - Electronic selector module																																	
CL-CLASS	215		Drive	DTR - Distronic																																	
CL-CLASS	215		Chassis	ABS/ESP - Electronic stability program																							V										
CL-CLASS	215		Chassis	Suspension																		V															
CL-CLASS	215		Chassis	PSE - Pneumatic system equipment																																	
CL-CLASS	215		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	215		Body	UCP - Upper control panel																																	
CL-CLASS	215		Body	System diagnosis																																	
CL-CLASS	215		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	215		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	215		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CL-CLASS	215		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	215		Body	RCM - Rear control module																				V													
CL-CLASS	215		Body	OCP - Overhead control panel																																	
CL-CLASS	215		Body	Multifunction control unit																																	
CL-CLASS	215		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	215		Body	HSW/LRH - Steering wheel heater																																	
CL-CLASS	215		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	215		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	215		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	215		Body	CGW - Central gateway																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
CL-CLASS	215		Body	AHE - Trailer recognition																																	
CL-CLASS	215		Body	AB - Airbag																																	
CL-CLASS	215		Information	TV - TV tuner																																	
CL-CLASS	215		Information	PTS - Parktronic system																																	
CL-CLASS	215		Information	NAV - Navigation module																																	
CL-CLASS	215		Information	IC - Instrument cluster								V	V				V																		V	
CL-CLASS	215		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	215		Information	AUDIO/COMAND																																	
CL-CLASS	215		Information	AGW - Audio gateway																																	
CL-CLASS	215		Seat/Door	OSB-FR - Multicontour backrest front right																																	
CL-CLASS	215		Seat/Door	OSB-FL - Multicontour backrest front left																																	
CL-CLASS	215		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	215		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	215		Seat/Door	DCM-FR - Door control module front right																				V													
CL-CLASS	215		Seat/Door	DCM-FL - Door control module front left																				V													
CL-CLASS	215		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	215		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
CL-CLASS	215		Air Conditioning	AAC - Automatic air conditioning							V																										
CL-CLASS	216		Drive	ME/CDI/CNG - Engine control unit											V	V			V										V	V		V	V	V			V
CL-CLASS	216		Drive	ETC - Electronic transmission control																					V												
CL-CLASS	216		Drive	ISM - Intelligent servo module																																	
CL-CLASS	216		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	216		Drive	DTR - Distronic																																	
CL-CLASS	216		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	216		Chassis	Suspension																																	
CL-CLASS	216		Chassis	ES - Electrical power steering																																	
CL-CLASS	216		Chassis	EFB - Electric parking brake																																	
CL-CLASS	216		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	216		Body	WSS - Weight sensing system																																	
CL-CLASS	216		Body	UCP - Upper control panel																																	
CL-CLASS	216		Body	System diagnosis																																	
CL-CLASS	216		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	216		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	216		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	216		Body	RCM - Rear control module																																	
CL-CLASS	216		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
CL-CLASS	216		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	216		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	216		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	216		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	216		Body	CGW - Central gateway																																	
CL-CLASS	216		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	216		Body	AHE - Trailer recognition																																	
CL-CLASS	216		Body	AB - Airbag																																	
CL-CLASS	216		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	216		Information	VCS - Voice control																																	
CL-CLASS	216		Information	TV - TV tuner																																	
CL-CLASS	216		Information	Tuner - Standard tuner																																	
CL-CLASS	216		Information	SGR - Radar sensors control unit																																	
CL-CLASS	216		Information	MFK - Multifunction camera																																	
CL-CLASS	216		Information	RFK - Backup camera																																	
CL-CLASS	216		Information	PTS - Parktronic system																																	
CL-CLASS	216		Information	NSA - Night View Assist																																	
CL-CLASS	216		Information	NBR-LF - Left front range radar																																	
CL-CLASS	216		Information	NAV - Navigation module																																	
CL-CLASS	216		Information	MIF/UCI - Media interface																																	
CL-CLASS	216		Information	ICI - InCar Internet																																	
CL-CLASS	216		Information	IC - Instrument cluster																																	
CL-CLASS	216		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	216		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	216		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	216		Information	AUDIO/COMAND																																	
CL-CLASS	216		Information	ASSYST PLUS - PLUS Active Service System																																	
CL-CLASS	216		Information	ASSYST Active Service System																																	
CL-CLASS	216		Seat/Door	TLC/GTO - Garage door opener																																	
CL-CLASS	216		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	216		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	216		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	216		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	216		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
CL-CLASS	216		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	216		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	216		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	217		Drive	SCR - Selective catalytic reduction																																	
CL-CLASS	217		Drive	SG-EM - Power electronics																																	
CL-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	217		Drive	DTR - Distronic																																	
CL-CLASS	217		Drive	ISM - Intelligent servo module																																	
CL-CLASS	217		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
CL-CLASS	217		Drive	ETC - Electronic transmission control																																	
CL-CLASS	217		Drive	PTCU - Common powertrain controller																																	
CL-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	217		Chassis	ABS/ESP - Electronic stability program																V																	
CL-CLASS	217		Chassis	ES - Electrical power steering																																	
CL-CLASS	217		Chassis	Suspension																																	
CL-CLASS	217		Chassis	EFB - Electric parking brake																																	
CL-CLASS	217		Information	TPAD - Touchpad																																	
CL-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	217		Information	360' - Camera																																	
CL-CLASS	217		Information	SOUND - Sound system																																	
CL-CLASS	217		Information	RFK - Backup camera																																	
CL-CLASS	217		Information	SGR - Radar sensors control unit																																	
CL-CLASS	217		Information	PTS - Parktronic system																																	
CL-CLASS	217		Information	NSA - Night View Assist																																	
CL-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CL-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CL-CLASS	217		Information	NBR-RF - Right front range radar																																	
CL-CLASS	217		Information	NBR-LF - Left front range radar																																	
CL-CLASS	217		Information	MFK - Multifunction camera																																	
CL-CLASS	217		Information	Head-up display																																	
CL-CLASS	217		Information	AUDIO/COMAND																																	
CL-CLASS	217		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	217		Information	KAB - Camera cover																																	
CL-CLASS	217		Information	IC - Instrument cluster																														V			
CL-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
CL-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CL-CLASS	217		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	AB - Airbag																																	
CL-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
CL-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	217		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	217		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
CL-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
CL-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	170		Drive	ME/CDI/CNG - Engine control unit																										V							
SLK-CLASS	170		Drive	ETC - Electronic transmission control																					V												
SLK-CLASS	170		Drive	ESM - Electronic selector module																																	
SLK-CLASS	170		Chassis	ABS/ESP - Electronic stability program																	V																
SLK-CLASS	170		Chassis	VP - Vacuum pump brake booster																																	
SLK-CLASS	170		Chassis	BAS - Brake assist																																	
SLK-CLASS	170		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	170		Body	AB - Airbag																																	
SLK-CLASS	170		Information	IC - Instrument cluster								V					V																				
SLK-CLASS	170		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	170		Information	AUDIO/COMAND																																	
SLK-CLASS	170		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
SLK-CLASS	170		Air Conditioning	AAC - Automatic air conditioning							V																										
SLK-CLASS	171		Drive	ME/CDI/CNG - Engine control unit															V											V		V					V
SLK-CLASS	171		Drive	ETC - Electronic transmission control																					V												
SLK-CLASS	171		Drive	ESM - Electronic selector module																																	
SLK-CLASS	171		Chassis	ABS/ESP - Electronic stability program																	V																
SLK-CLASS	171		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	171		Body	WSS - Weight sensing system																																	
SLK-CLASS	171		Body	UCP - Upper control panel																																	
SLK-CLASS	171		Body	System diagnosis																																	
SLK-CLASS	171		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	171		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	171		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																							V										
SLK-CLASS	171		Body	OCP - Overhead control panel	V																																
SLK-CLASS	171		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	171		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	171		Body	CGW - Central gateway																																	
SLK-CLASS	171		Body	AB - Airbag																																	
SLK-CLASS	171		Information	TV - TV tuner																																	
SLK-CLASS	171		Information	SOUND - Sound system																																	
SLK-CLASS	171		Information	PTS - Parktronic system																																	
SLK-CLASS	171		Information	MIF/UCI - Media interface																																	
SLK-CLASS	171		Information	IC - Instrument cluster									V	V																							
SLK-CLASS	171		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	171		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	171		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SLK-CLASS	171		Information	AUDIO/COMAND																																	
SLK-CLASS	171		Information	ASSYST PLUS - PLUS Active Service System																																	
SLK-CLASS	171		Information	ASSYST Active Service System									V																								
SLK-CLASS	171		Information	AGW - Audio gateway																																	
SLK-CLASS	171		Seat/Door	RVC/VDS - Convertible roof control																				V													
SLK-CLASS	171		Seat/Door	HS - Seat heater																																	
SLK-CLASS	171		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger		V	V	V	V	V																											
SLK-CLASS	171		Seat/Door	ESA Driver - Electric seat adjustment Driver		V	V	V	V	V																											
SLK-CLASS	171		Seat/Door	DCM-FR - Door control module front right																				V													
SLK-CLASS	171		Seat/Door	DCM-FL - Door control module front left																				V													
SLK-CLASS	171		Air Conditioning	AAC - Automatic air conditioning							V																										

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
SLK-CLASS	172		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
SLK-CLASS	172		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	172		Drive	ESM - Electronic selector module																																	
SLK-CLASS	172		Drive	DTR - Distronic																																	
SLK-CLASS	172		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLK-CLASS	172		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	172		Chassis	Suspension																																	
SLK-CLASS	172		Chassis	ES - Electrical power steering																																	
SLK-CLASS	172		Chassis	EFB - Electric parking brake																																	
SLK-CLASS	172		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	172		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	172		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	172		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLK-CLASS	172		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	172		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLK-CLASS	172		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	172		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	172		Body	CGW - Central gateway																																	
SLK-CLASS	172		Body	AB - Airbag																																	
SLK-CLASS	172		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SLK-CLASS	172		Information	ZAN - Audio/COMAND display																																	
SLK-CLASS	172		Information	TV - TV tuner																																	
SLK-CLASS	172		Information	SOUND - Sound system																																	
SLK-CLASS	172		Information	SGR - Radar sensors control unit																																	
SLK-CLASS	172		Information	MFK - Multifunction camera																																	
SLK-CLASS	172		Information	PTS - Parktronic system																																	
SLK-CLASS	172		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLK-CLASS	172		Information	NBR-RF - Right front range radar																																	
SLK-CLASS	172		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLK-CLASS	172		Information	NBR-LF - Left front range radar																																	
SLK-CLASS	172		Information	NAV - Navigation module																																	
SLK-CLASS	172		Information	MIF/UCI - Media interface																																	
SLK-CLASS	172		Information	IC - Instrument cluster																														V			
SLK-CLASS	172		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
SLK-CLASS	172		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	172		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLK-CLASS	172		Information	AUDIO/COMAND																																	
SLK-CLASS	172		Seat/Door	RVC/VDS - Convertible roof control																																	
SLK-CLASS	172		Seat/Door	PSD/MSC - Sliding roof control																																	
SLK-CLASS	172		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	172		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	172		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	172		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	172		Air Conditioning	AAC - Automatic air conditioning																			V														
SL-CLASS	129		Drive	ME/CDI/CNG - Engine control unit																																	
SL-CLASS	129		Drive	ETC - Electronic transmission control																																	
SL-CLASS	129		Chassis	ABS/ESP - Electronic stability program																							V										
SL-CLASS	129		Chassis	BAS - Brake assist																																	
SL-CLASS	129		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	129		Body	AB - Airbag																																	
SL-CLASS	129		Information	NAV - Navigation module																																	
SL-CLASS	129		Information	IC - Instrument cluster								V	V				V																			V	
SL-CLASS	129		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	129		Information	AUDIO/COMAND																																	
SL-CLASS	129		Information	APS - Auto pilot system																																	
SL-CLASS	129		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	129		Air Conditioning	AAC - Automatic air conditioning							V																										
SL-CLASS	230		Drive	ME/CDI/CNG - Engine control unit															V											V		V					V
SL-CLASS	230		Drive	ETC - Electronic transmission control																					V												
SL-CLASS	230		Drive	ESM - Electronic selector module																																	
SL-CLASS	230		Drive	DTR - Distronic																																	
SL-CLASS	230		Drive	AMG DRIVE UNIT																																	
SL-CLASS	230		Chassis	ABS/ESP - Electronic stability program																	V																
SL-CLASS	230		Chassis	Suspension																		V															
SL-CLASS	230		Chassis	SBC - Sensotronic Brake Control																																	
SL-CLASS	230		Chassis	PSE - Pneumatic system equipment																																	
SL-CLASS	230		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	230		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	230		Body	WSS - Weight sensing system																																	
SL-CLASS	230		Body	System diagnosis																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
SL-CLASS	230		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	230		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	230		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SL-CLASS	230		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	230		Body	OCP - Overhead control panel																																	
SL-CLASS	230		Body	LCP/HBF - Lower/Rear control panel																																	
SL-CLASS	230		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	230		Body	HSW/LRH - Steering wheel heater																																	
SL-CLASS	230		Body	Headlamp-R - Headlamp control unit																																	
SL-CLASS	230		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	230		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	230		Body	CGW - Central gateway																																	
SL-CLASS	230		Body	BNS/BMS - Battery sensor																																	
SL-CLASS	230		Body	AB - Airbag																																	
SL-CLASS	230		Information	TV - TV tuner																																	
SL-CLASS	230		Information	SOUND - Sound system																																	
SL-CLASS	230		Information	PTS - Parktronic system																																	
SL-CLASS	230		Information	MIF/UCI - Media interface																																	
SL-CLASS	230		Information	IC - Instrument cluster									V				V																			V	
SL-CLASS	230		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	230		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	230		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SL-CLASS	230		Information	AUDIO/COMAND																																	
SL-CLASS	230		Information	AGW - Audio gateway																																	
SL-CLASS	230		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	230		Seat/Door	OSB-FR - Multicontour backrest front right																																	
SL-CLASS	230		Seat/Door	OSB-FL - Multicontour backrest front left																																	
SL-CLASS	230		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	230		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	230		Seat/Door	DCM-FR - Door control module front right																				V													
SL-CLASS	230		Seat/Door	DCM-FL - Door control module front left																				V													
SL-CLASS	230		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	230		Air Conditioning	AAC - Automatic air conditioning							V																										
SL-CLASS	231		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
SL-CLASS	231		Drive	ETC - Electronic transmission control																																	
SL-CLASS	231		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
SL-CLASS	231		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SL-CLASS	231		Drive	DTR - Distronic																																	
SL-CLASS	231		Drive	DSI - Direct select interface																																	
SL-CLASS	231		Drive	AMG DRIVE UNIT																																	
SL-CLASS	231		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	231		Chassis	Suspension																																	
SL-CLASS	231		Chassis	ES - Electrical power steering																																	
SL-CLASS	231		Chassis	EFB - Electric parking brake																																	
SL-CLASS	231		Chassis	FWGW - Chassis gateway																																	
SL-CLASS	231		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	231		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	231		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	231		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	231		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	231		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	231		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	231		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	231		Body	CGW - Central gateway																																	
SL-CLASS	231		Body	AB - Airbag																																	
SL-CLASS	231		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SL-CLASS	231		Information	ZAN - Audio/COMAND display																																	
SL-CLASS	231		Information	TV - TV tuner																																	
SL-CLASS	231		Information	SOUND - Sound system																																	
SL-CLASS	231		Information	SGR - Radar sensors control unit																																	
SL-CLASS	231		Information	RFK - Backup camera																																	
SL-CLASS	231		Information	MFK - Multifunction camera																																	
SL-CLASS	231		Information	PTS - Parktronic system																																	
SL-CLASS	231		Information	NSA - Night View Assist																																	
SL-CLASS	231		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SL-CLASS	231		Information	NBR-RF - Right front range radar																																	
SL-CLASS	231		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SL-CLASS	231		Information	NBR-LF - Left front range radar																																	
SL-CLASS	231		Information	MIF/UCI - Media interface																																	
SL-CLASS	231		Information	IC - Instrument cluster																															V		

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
SL-CLASS	231		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	231		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	231		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SL-CLASS	231		Information	AUDIO/COMAND																																	
SL-CLASS	231		Information	AMG Performance Media																																	
SL-CLASS	231		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	231		Seat/Door	PSD/MSC - Sliding roof control																																	
SL-CLASS	231		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	231		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	231		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
SL-CLASS	231		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	231		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	231		Air Conditioning	AAC - Automatic air conditioning																			V														
SLS-CLASS	197		Drive	PTCU - Common powertrain controller																																	
SLS-CLASS	197		Drive	ME/CDI/CNG - Engine control unit															V											V		V					V
SLS-CLASS	197		Drive	ETC - Electronic transmission control																																	
SLS-CLASS	197		Drive	ISM - Intelligent servo module																																	
SLS-CLASS	197		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLS-CLASS	197		Drive	DSI - Direct select interface																																	
SLS-CLASS	197		Drive	AMG DRIVE UNIT																																	
SLS-CLASS	197		Chassis	ABS/ESP - Electronic stability program																																	
SLS-CLASS	197		Chassis	Suspension																																	
SLS-CLASS	197		Chassis	ES - Electrical power steering																																	
SLS-CLASS	197		Chassis	EFB - Electric parking brake																																	
SLS-CLASS	197		Chassis	TPM - Tire pressure monitor																																	
SLS-CLASS	197		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	CSHV - Crash sensor/high-voltage battery																																	
SLS-CLASS	197		Body	BNS/BMS - Battery sensor											V	V													V			V	V	V			V
SLS-CLASS	197		Body	WSS - Weight sensing system																																	
SLS-CLASS	197		Body	SCM [MRM] - Steering column module																																	
SLS-CLASS	197		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLS-CLASS	197		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLS-CLASS	197		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
SLS-CLASS	197		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLS-CLASS	197		Body	EZS/EIS - Electronic ignition lock																																	
SLS-CLASS	197		Body	CGW - Central gateway																																	
SLS-CLASS	197		Body	AB - Airbag																																	
SLS-CLASS	197		Information	MFK - Multifunction camera																																	
SLS-CLASS	197		Information	SGR - Radar sensors control unit																																	
SLS-CLASS	197		Information	ZAN - Audio/COMAND display																																	
SLS-CLASS	197		Information	SOUND - Sound system																																	
SLS-CLASS	197		Information	PTS - Parktronic system																																	
SLS-CLASS	197		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLS-CLASS	197		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLS-CLASS	197		Information	MIF/UCI - Media interface																																	
SLS-CLASS	197		Information	IC - Instrument cluster																														V			
SLS-CLASS	197		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLS-CLASS	197		Information	DAB/SDAR - Digital/Satellite radio																																	
SLS-CLASS	197		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLS-CLASS	197		Information	AUDIO/COMAND																																	
SLS-CLASS	197		Information	AMG Performance Media																																	
SLS-CLASS	197		Seat/Door	RVC/VDS - Convertible roof control																																	
SLS-CLASS	197		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLS-CLASS	197		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLS-CLASS	197		Seat/Door	DCM-FR - Door control module front right																																	
SLS-CLASS	197		Seat/Door	DCM-FL - Door control module front left																																	
SLS-CLASS	197		Air Conditioning	AAC - Automatic air conditioning																			V														
AMG GT	190		Drive	DTR - Distronic																																	
AMG GT	190		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
AMG GT	190		Drive	DSI - Direct select interface																																	
AMG GT	190		Drive	AMG DRIVE UNIT																																	
AMG GT	190		Drive	PTCU - Common powertrain controller																																	
AMG GT	190		Drive	ME/CDI/CNG - Engine control unit											V	V													V			V	V	V			V
AMG GT	190		Drive	ETC - Electronic transmission control																																	
AMG GT	190		Chassis	TPM - Tire pressure monitor																																	
AMG GT	190		Chassis	Suspension																																	
AMG GT	190		Chassis	ABS/ESP - Electronic stability program																																	
AMG GT	190		Chassis	EFB - Electric parking brake																																	
AMG GT	190		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
AMG GT	190		Information	DAB/SDAR - Digital/Satellite radio																																	
AMG GT	190		Information	SOUND - Sound system																																	
AMG GT	190		Information	RFK - Backup camera																																	
AMG GT	190		Information	PTS - Parktronic system																																	
AMG GT	190		Information	MFK - Multifunction camera																																	
AMG GT	190		Information	IC - Instrument cluster																															V		
AMG GT	190		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
AMG GT	190		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
AMG GT	190		Information	AUDIO/COMAND																																	
AMG GT	190		Information	ZAN - Audio/COMAND display																																	
AMG GT	190		Information	COU [ZBE] - Audio/COMAND operating unit																																	
AMG GT	190		Information	DTA - Mbrace or TELEAID/GPS Box																																	
AMG GT	190		Information	AMG Performance Media																																	
AMG GT	190		Body	SCM [MRM] - Steering column module																																	
AMG GT	190		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
AMG GT	190		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
AMG GT	190		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
AMG GT	190		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
AMG GT	190		Body	AB - Airbag																																	
AMG GT	190		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
AMG GT	190		Body	Headlamp-R - Headlamp control unit																																	
AMG GT	190		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
AMG GT	190		Body	SG-AWF - Collision prevention assist																																	
AMG GT	190		Body	EZS/EIS - Electronic ignition lock																																	
AMG GT	190		Body	CGW - Central gateway																																	
AMG GT	190		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
AMG GT	190		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
AMG GT	190		Seat/Door	DCM-FR - Door control module front right																																	
AMG GT	190		Seat/Door	DCM-FL - Door control module front left																																	
AMG GT	190		Air Conditioning	AAC - Automatic air conditioning																			V														
SLR-CLASS	199		Drive	ME/CDI/CNG - Engine control unit																																	
SLR-CLASS	199		Drive	ETC - Electronic transmission control																					V												
SLR-CLASS	199		Drive	ESM - Electronic selector module																																	
SLR-CLASS	199		Chassis	ABS/ESP - Electronic stability program																																	
SLR-CLASS	199		Chassis	SBC - Sensotronic Brake Control																																	
SLR-CLASS	199		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
SLR-CLASS	199		Body	WSS - Weight sensing system																																	
SLR-CLASS	199		Body	SCM [MRM] - Steering column module																																	
SLR-CLASS	199		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLR-CLASS	199		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SLR-CLASS	199		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLR-CLASS	199		Body	OCP - Overhead control panel																																	
SLR-CLASS	199		Body	LCP/HBF - Lower/Rear control panel																																	
SLR-CLASS	199		Body	Headlamp-R - Headlamp control unit																																	
SLR-CLASS	199		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLR-CLASS	199		Body	EZS/EIS - Electronic ignition lock																																	
SLR-CLASS	199		Body	CGW - Central gateway																																	
SLR-CLASS	199		Body	BNS/BMS - Battery sensor																																	
SLR-CLASS	199		Body	AB - Airbag																																	
SLR-CLASS	199		Information	IC - Instrument cluster									V				V																			V	
SLR-CLASS	199		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLR-CLASS	199		Information	AUDIO/COMAND																																	
SLR-CLASS	199		Seat/Door	DCM-FR - Door control module front right																				V													
SLR-CLASS	199		Seat/Door	DCM-FL - Door control module front left																				V													
SLR-CLASS	199		Air Conditioning	AAC - Automatic air conditioning							V																										
MAYBACH	240		Drive	ME/CDI/CNG - Engine control unit															V										V		V						V
MAYBACH	240		Drive	ETC - Electronic transmission control																					V												
MAYBACH	240		Drive	ESM - Electronic selector module																																	
MAYBACH	240		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
MAYBACH	240		Drive	DTR - Distronic																						V	V	V	V	V	V	V	V	V	V	V	V
MAYBACH	240		Chassis	ABS/ESP - Electronic stability program																																	
MAYBACH	240		Chassis	Suspension																																	
MAYBACH	240		Chassis	SBC - Sensotronic Brake Control																																	
MAYBACH	240		Chassis	TPM - Tire pressure monitor																																	
MAYBACH	240		Body	WSS - Weight sensing system																																	
MAYBACH	240		Body	System diagnosis																																	
MAYBACH	240		Body	SCM [MRM] - Steering column module																																	
MAYBACH	240		Body	HSW/LRH - Steering wheel heater																																	
MAYBACH	240		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
MAYBACH	240		Body	AB - Airbag																																	
MAYBACH	240		Information	TV - TV tuner																																	
MAYBACH	240		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
MAYBACH	240		Information	DTA - Mbrace or TELEAID/GPS Box																																	
MAYBACH	240		Information	AGW - Audio gateway																																	
MAYBACH	240		Seat/Door	REDC/RWT - Rear end door control module																																	
MAYBACH	240		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All_Model(BETA)	16P Connector		Drive	SG-EM - Power electronics																																	
All_Model(BETA)	16P Connector		Drive	HFPM - Haptic accelerator pedal module																																	
All_Model(BETA)	16P Connector		Drive	ME/CDI/CNG - Engine control unit											V	V			V										V	V		V	V	V			V
All_Model(BETA)	16P Connector		Drive	ETC - Electronic transmission control																					V												
All_Model(BETA)	16P Connector		Drive	ESM - Electronic selector module																																	
All_Model(BETA)	16P Connector		Drive	VG - Transfer case																																	
All_Model(BETA)	16P Connector		Drive	VECU - Power monitoring control unit																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-B - Electric motor control unit B																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-A - Electric motor control unit A																																	
All_Model(BETA)	16P Connector		Drive	SCR - Selective catalytic reduction																																	
All_Model(BETA)	16P Connector		Drive	PTCU - Common powertrain controller																																	
All_Model(BETA)	16P Connector		Drive	Natural gas control unit																																	
All_Model(BETA)	16P Connector		Drive	ISM - Intelligent servo module																																	
All_Model(BETA)	16P Connector		Drive	Hydrogen tank control unit																																	
All_Model(BETA)	16P Connector		Drive	HSG - Hybrid control unit															V																		
All_Model(BETA)	16P Connector		Drive	High-temperature coolant pump control unit																																	
All_Model(BETA)	16P Connector		Drive	Fuel cell control unit																																	
All_Model(BETA)	16P Connector		Drive	FSCU-R - Control unit fuel pump																																	
All_Model(BETA)	16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
All_Model(BETA)	16P Connector		Drive	EMPI - Electronic Motor Pump Inverter																																	
All_Model(BETA)	16P Connector		Drive	Electric drive control unit																																	
All_Model(BETA)	16P Connector		Drive	DTR - Distronic																																	
All_Model(BETA)	16P Connector		Drive	DSI - Direct select interface																																	
All_Model(BETA)	16P Connector		Drive	Compressed Natural Gas Control Module																																	
All_Model(BETA)	16P Connector		Drive	CC - Cruise control																																	
All_Model(BETA)	16P Connector		Drive	BSA - Belt-driven starter/alternator																																	
All_Model(BETA)	16P Connector		Drive	AMG DRIVE UNIT																																	
All_Model(BETA)	16P Connector		Drive	ACS - Automatic clutch system																																	
All_Model(BETA)	16P Connector		Chassis	ABS/ESP - Electronic stability program																	V						V										
All_Model(BETA)	16P Connector		Chassis	Suspension																		V															
All_Model(BETA)	16P Connector		Chassis	SBC - Sensotronic Brake Control																																	
All_Model(BETA)	16P Connector		Chassis	PSE - Pneumatic system equipment																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
All_Model(BETA)	16P Connector		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
All_Model(BETA)	16P Connector		Chassis	HAQ - Interwheel differential lock at rear axle																																	
All_Model(BETA)	16P Connector		Chassis	FWGW - Chassis gateway																																	
All_Model(BETA)	16P Connector		Chassis	ES - Electrical power steering																																	
All_Model(BETA)	16P Connector		Chassis	EFB - Electric parking brake																																	
All_Model(BETA)	16P Connector		Chassis	BAS - Brake assist																																	
All_Model(BETA)	16P Connector		Chassis	VP - Vacuum pump brake booster																																	
All_Model(BETA)	16P Connector		Chassis	TPM - Tire pressure monitor																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
All_Model(BETA)	16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
All_Model(BETA)	16P Connector		Body	CSHV - Crash sensor/high-voltage battery																																	
All_Model(BETA)	16P Connector		Body	WSS - Weight sensing system																																	
All_Model(BETA)	16P Connector		Body	UCP - Upper control panel																																	
All_Model(BETA)	16P Connector		Body	System diagnosis																																	
All_Model(BETA)	16P Connector		Body	SG-DDW - DC/DC converter control unit																																	
All_Model(BETA)	16P Connector		Body	SG-AWF - Collision prevention assist																																	
All_Model(BETA)	16P Connector		Body	SCM [MRM] - Steering column module																																	
All_Model(BETA)	16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
All_Model(BETA)	16P Connector		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
All_Model(BETA)	16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																							V										
All_Model(BETA)	16P Connector		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
All_Model(BETA)	16P Connector		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
All_Model(BETA)	16P Connector		Body	RCM - Rear control module																				V													
All_Model(BETA)	16P Connector		Body	OCP - Overhead control panel	V																																
All_Model(BETA)	16P Connector		Body	Multifunction control unit																																	
All_Model(BETA)	16P Connector		Body	LCP/HBF - Lower/Rear control panel																																	
All_Model(BETA)	16P Connector		Body	LAE [LAA] - Loading floor automatically extendable																																	
All_Model(BETA)	16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
All_Model(BETA)	16P Connector		Body	HSW/LRH - Steering wheel heater																																	
All_Model(BETA)	16P Connector		Body	Headlamp-R - Headlamp control unit																																	
All_Model(BETA)	16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
All_Model(BETA)	16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
All_Model(BETA)	16P Connector		Body	CGW - Central gateway																																	
All_Model(BETA)	16P Connector		Body	BNS/BMS - Battery sensor																																	
All_Model(BETA)	16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
All_Model(BETA)	16P Connector		Body	AHE - Trailer recognition																																	
All_Model(BETA)	16P Connector		Body	AB - Airbag																																	
All_Model(BETA)	16P Connector		Body	AAM - All activity module																																	
All_Model(BETA)	16P Connector		Information	TPAD - Touchpad																																	
All_Model(BETA)	16P Connector		Information	Head-up display																																	
All_Model(BETA)	16P Connector		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
All_Model(BETA)	16P Connector		Information	KAB - Camera cover																																	
All_Model(BETA)	16P Connector		Information	ZAN - Audio/COMAND display																																	
All_Model(BETA)	16P Connector		Information	VCS - Voice control																																	
All_Model(BETA)	16P Connector		Information	TV - TV tuner																																	
All_Model(BETA)	16P Connector		Information	Tuner - Standard tuner																																	
All_Model(BETA)	16P Connector		Information	Sound generator for exhaust system																																	
All_Model(BETA)	16P Connector		Information	SOUND - Sound system																																	
All_Model(BETA)	16P Connector		Information	SGR - Radar sensors control unit																																	
All_Model(BETA)	16P Connector		Information	360' - Camera																																	
All_Model(BETA)	16P Connector		Information	MFK - Multifunction camera																																	
All_Model(BETA)	16P Connector		Information	RFK - Backup camera																																	
All_Model(BETA)	16P Connector		Information	PTS - Parktronic system																																	
All_Model(BETA)	16P Connector		Information	NSA - Night View Assist																																	
All_Model(BETA)	16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-RF - Right front range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LF - Left front range radar																																	
All_Model(BETA)	16P Connector		Information	NAV - Navigation module																																	
All_Model(BETA)	16P Connector		Information	MIF/UCI - Media interface																																	
All_Model(BETA)	16P Connector		Information	ICI - InCar Internet																																	
All_Model(BETA)	16P Connector		Information	IC - Instrument cluster								V	V	V			V																		V	V	
All_Model(BETA)	16P Connector		Information	DVD player																																	
All_Model(BETA)	16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
All_Model(BETA)	16P Connector		Information	D-FOR - Display in right rear passenger																																	
All_Model(BETA)	16P Connector		Information	D-FOL - Display in left rear passenger																																	
All_Model(BETA)	16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
All_Model(BETA)	16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
All_Model(BETA)	16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
All_Model(BETA)	16P Connector		Information	CM - Compass module																																	
All_Model(BETA)	16P Connector		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter
All Model(BETA)	16P Connector		Information	AUDIO/COMAND																																	
All Model(BETA)	16P Connector		Information	ASSYST PLUS - PLUS Active Service System																																	
All Model(BETA)	16P Connector		Information	ASSYST Active Service System									V																								
All Model(BETA)	16P Connector		Information	APS - Auto pilot system																																	
All Model(BETA)	16P Connector		Information	AMG Performance Media																																	
All Model(BETA)	16P Connector		Information	AGW - Audio gateway																																	
All Model(BETA)	16P Connector		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-MR - Right center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-ML - Left center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TLC/GTO - Garage door opener																																	
All Model(BETA)	16P Connector		Seat/Door	RVC/VDS - Convertible roof control																																	
All Model(BETA)	16P Connector		Seat/Door	REDC/RWT - Rear end door control module																																	
All Model(BETA)	16P Connector		Seat/Door	PSD/MSC - Sliding roof control																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-R - Multicontour backrest rear																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FR - Multicontour backrest front right																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FL - Multicontour backrest front left																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	HS - Seat heater																																	
All Model(BETA)	16P Connector		Seat/Door	HKS - Tailgate control																																	
All Model(BETA)	16P Connector		Seat/Door	ESA-R - Electric seat adjustment rear																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger		V	V	V	V	V																											
All Model(BETA)	16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
All Model(BETA)	16P Connector		Seat/Door	ERA - Electric fold down backrest system		V	V	V	V	V																											
All Model(BETA)	16P Connector		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-RR - Door control module rear right																				V													
All Model(BETA)	16P Connector		Seat/Door	DCM-RL - Door control module rear left																				V													
All Model(BETA)	16P Connector		Seat/Door	DCM-FR - Door control module front right																				V													
All Model(BETA)	16P Connector		Seat/Door	DCM-FL - Door control module front left																				V													
All Model(BETA)	16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All Model(BETA)	16P Connector		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
All Model(BETA)	16P Connector		Air Conditioning	HBF - Rear control panel																																	
All Model(BETA)	16P Connector		Air Conditioning	HB - Heater booster																																	
All Model(BETA)	16P Connector		Air Conditioning	EKMK - Electric refrigerant compressor																																	
All Model(BETA)	16P Connector		Air Conditioning	AAC - Automatic air conditioning							V												V														

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
A-CLASS	68		Drive	ME/CDI/CNG - Engine control unit																																	
A-CLASS	68		Drive	ETC - Electronic transmission control																																	
A-CLASS	68		Drive	ESM - Electronic selector module																																	
A-CLASS	68		Drive	ACS - Automatic clutch system																																	
A-CLASS	68		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Body	LCP/HBF - Lower/Rear control panel																																	
A-CLASS	168		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	168		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	168		Body	AB - Airbag																																	
A-CLASS	168		Information	PTS - Parktronic system																																	
A-CLASS	168		Information	IC - Instrument cluster																V																	
A-CLASS	168		Information	AUDIO/COMAND																																	
A-CLASS	168		Information	APS - Auto pilot system																																	
A-CLASS	168		Seat/Door	DCM-RR - Door control module rear right																																	
A-CLASS	168		Seat/Door	DCM-RL - Door control module rear left																																	
A-CLASS	168		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	168		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	168		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	168		Air Conditioning	HB - Heater booster																																	
A-CLASS	168		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	169		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V												V		V	V	V				V
A-CLASS	169		Drive	ETC - Electronic transmission control																						V	V										
A-CLASS	169		Drive	ESM - Electronic selector module																																	
A-CLASS	169		Drive	BSA - Belt-driven starter/alternator																																	
A-CLASS	169		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	169		Chassis	ES - Electrical power steering																																	
A-CLASS	169		Body	SCM [MRM] - Steering column module																																	
A-CLASS	169		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
A-CLASS	169		Body	OCP - Overhead control panel																																	
A-CLASS	169		Body	Multifunction control unit																																	
A-CLASS	169		Body	Headlamp-R - Headlamp control unit																																	
A-CLASS	169		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
A-CLASS	169		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	169		Body	CGW - Central gateway																																	
A-CLASS	169		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
A-CLASS	169		Body	AHE - Trailer recognition																																	
A-CLASS	169		Body	AB - Airbag																																	
A-CLASS	169		Information	SOUND - Sound system																																	
A-CLASS	169		Information	PTS - Parktronic system																																	
A-CLASS	169		Information	MIF/UCI - Media interface																																	
A-CLASS	169		Information	IC - Instrument cluster																																	
A-CLASS	169		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	169		Information	CTEL/TEL - Cellular/Mobile telephone																																	
A-CLASS	169		Information	AUDIO/COMAND																																	
A-CLASS	169		Information	ASSYST PLUS - PLUS Active Service System														V																			
A-CLASS	169		Information	ASSYST Active Service System																																	
A-CLASS	169		Information	AGW - Audio gateway																																	
A-CLASS	169		Seat/Door	DCM-RR - Door control module rear right																																	
A-CLASS	169		Seat/Door	DCM-RL - Door control module rear left																									V								
A-CLASS	169		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	169		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	169		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	176		Drive	VG - Transfer case																																	
A-CLASS	176		Drive	ME/CDI/CNG - Engine control unit									V		V		V													V		V	V	V			V
A-CLASS	176		Drive	ETC - Electronic transmission control																															V		
A-CLASS	176		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
A-CLASS	176		Drive	DTR - Distronic																																	
A-CLASS	176		Drive	DSI - Direct select interface																																	
A-CLASS	176		Drive	PTCU - Common powertrain controller																																	
A-CLASS	176		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	176		Chassis	ES - Electrical power steering										V								V															
A-CLASS	176		Chassis	EFB - Electric parking brake																																	
A-CLASS	176		Chassis	TPM - Tire pressure monitor																																	
A-CLASS	176		Body	SG-AWF - Collision prevention assist																																	
A-CLASS	176		Body	SCM [MRM] - Steering column module																																	
A-CLASS	176		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
A-CLASS	176		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	Multifunction control unit																																	
A-CLASS	176		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	176		Body	Headlamp/Headlamp-L - Headlamp control unit																				V													

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
A-CLASS	176		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	176		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	176		Body	AHE - Trailer recognition																																	
A-CLASS	176		Body	AB - Airbag																																	
A-CLASS	176		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
A-CLASS	176		Information	ZAN - Audio/COMAND display																																	
A-CLASS	176		Information	TV - TV tuner																																	
A-CLASS	176		Information	SOUND - Sound system																																	
A-CLASS	176		Information	RFK - Backup camera																																	
A-CLASS	176		Information	MFK - Multifunction camera																																	
A-CLASS	176		Information	PTS - Parktronic system																																	
A-CLASS	176		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
A-CLASS	176		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
A-CLASS	176		Information	NAV - Navigation module																																	
A-CLASS	176		Information	MIF/UCI - Media interface																																	
A-CLASS	176		Information	IC - Instrument cluster														V	V																		
A-CLASS	176		Information	DTA - Mbrace or TELEAID/GPS Box																																	
A-CLASS	176		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	176		Information	COU [ZBE] - Audio/COMAND operating unit																																	
A-CLASS	176		Information	AUDIO/COMAND																																	
A-CLASS	176		Seat/Door	PSD/MSC - Sliding roof control																																	
A-CLASS	176		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
A-CLASS	176		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
A-CLASS	176		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	176		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	176		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	176		Air Conditioning	AAC - Automatic air conditioning																																	
B-CLASS	245		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V																	V		V		V				V
B-CLASS	245		Drive	ETC - Electronic transmission control																					V	V											
B-CLASS	245		Drive	ESM - Electronic selector module																																	
B-CLASS	245		Drive	Hydrogen tank control unit																																	
B-CLASS	245		Drive	High-temperature coolant pump control unit																																	
B-CLASS	245		Drive	Fuel cell control unit																																	
B-CLASS	245		Drive	Electric drive control unit																																	
B-CLASS	245		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	245		Drive	BSA - Belt-driven starter/alternator																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
B-CLASS	245		Drive	VECU - Power monitoring control unit																																	
B-CLASS	245		Chassis	ABS/ESP - Electronic stability program																																	
B-CLASS	245		Chassis	ES - Electrical power steering																																	
B-CLASS	245		Chassis	VP - Vacuum pump brake booster																																	
B-CLASS	245		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	245		Body	WSS - Weight sensing system																																	
B-CLASS	245		Body	SG-DDW - DC/DC converter control unit																																	
B-CLASS	245		Body	SCM [MRM] - Steering column module																																	
B-CLASS	245		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
B-CLASS	245		Body	OCP - Overhead control panel																																	
B-CLASS	245		Body	Multifunction control unit																																	
B-CLASS	245		Body	Headlamp-R - Headlamp control unit																								V									
B-CLASS	245		Body	Headlamp/Headlamp-L - Headlamp control unit																								V									
B-CLASS	245		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	245		Body	CGW - Central gateway																																	
B-CLASS	245		Body	BNS/BMS - Battery sensor																																	
B-CLASS	245		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	245		Body	AHE - Trailer recognition																																	
B-CLASS	245		Body	AB - Airbag																																	
B-CLASS	245		Information	SOUND - Sound system																																	
B-CLASS	245		Information	PTS - Parktronic system																																	
B-CLASS	245		Information	NAV - Navigation module																																	
B-CLASS	245		Information	MIF/UCI - Media interface																																	
B-CLASS	245		Information	IC - Instrument cluster																																	
B-CLASS	245		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	245		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	245		Information	CTEL/TEL - Cellular/Mobile telephone																																	
B-CLASS	245		Information	CM - Compass module																																	
B-CLASS	245		Information	AUDIO/COMAND																																	
B-CLASS	245		Information	ASSYST PLUS - PLUS Active Service System														V																			
B-CLASS	245		Information	ASSYST Active Service System																																	
B-CLASS	245		Information	AGW - Audio gateway																																	
B-CLASS	245		Seat/Door	DCM-RR - Door control module rear right																																	
B-CLASS	245		Seat/Door	DCM-RL - Door control module rear left																									V								
B-CLASS	245		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	245		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
B-CLASS	245		Air Conditioning	EKMK - Electric refrigerant compressor																																	
B-CLASS	245		Air Conditioning	AAC - Automatic air conditioning																																	
B-CLASS	246		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	246		Drive	VG - Transfer case																																	
B-CLASS	246		Drive	ME/CDI/CNG - Engine control unit									V		V		V													V		V	V	V			V
B-CLASS	246		Drive	ETC - Electronic transmission control																																V	
B-CLASS	246		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
B-CLASS	246		Drive	DTR - Distronic																																	
B-CLASS	246		Drive	PTCU - Common powertrain controller																																	
B-CLASS	246		Chassis	ABS/ESP - Electronic stability program																																	
B-CLASS	246		Chassis	ES - Electrical power steering										V								V															
B-CLASS	246		Chassis	EFB - Electric parking brake																																	
B-CLASS	246		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	246		Body	BNS/BMS - Battery sensor																																	
B-CLASS	246		Body	SG-AWF - Collision prevention assist																																	
B-CLASS	246		Body	SCM [MRM] - Steering column module																																	
B-CLASS	246		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
B-CLASS	246		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	Multifunction control unit																																	
B-CLASS	246		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
B-CLASS	246		Body	Headlamp-R - Headlamp control unit																				V													
B-CLASS	246		Body	Headlamp/Headlamp-L - Headlamp control unit																				V													
B-CLASS	246		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	246		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	246		Body	AHE - Trailer recognition																																	
B-CLASS	246		Body	AB - Airbag																																	
B-CLASS	246		Information	Sound generator for exhaust system																																	
B-CLASS	246		Information	Head-up display																																	
B-CLASS	246		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
B-CLASS	246		Information	ZAN - Audio/COMAND display																																	
B-CLASS	246		Information	TV - TV tuner																																	
B-CLASS	246		Information	SOUND - Sound system																																	
B-CLASS	246		Information	RFK - Backup camera																																	
B-CLASS	246		Information	MFK - Multifunction camera																																	
B-CLASS	246		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
B-CLASS	246		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
B-CLASS	246		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
B-CLASS	246		Information	NAV - Navigation module																																	
B-CLASS	246		Information	MIF/UCI - Media interface																																	
B-CLASS	246		Information	IC - Instrument cluster														V	V																		
B-CLASS	246		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	246		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	246		Information	COU [ZBE] - Audio/COMAND operating unit																																	
B-CLASS	246		Information	AUDIO/COMAND																																	
B-CLASS	246		Seat/Door	PSD/MSC - Sliding roof control																																	
B-CLASS	246		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
B-CLASS	246		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
B-CLASS	246		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	246		Seat/Door	DCM-FL - Door control module front left																																	
B-CLASS	246		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
B-CLASS	246		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	202		Drive	ME/CDI/CNG - Engine control unit																																	
C-CLASS	202		Drive	ETC - Electronic transmission control																						V	V										
C-CLASS	202		Drive	ESM - Electronic selector module																																	
C-CLASS	202		Chassis	PSE - Pneumatic system equipment																																	
C-CLASS	202		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	202		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	202		Chassis	BAS - Brake assist																																	
C-CLASS	202		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	202		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	202		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	202		Body	OCP - Overhead control panel																																	
C-CLASS	202		Body	AB - Airbag																																	
C-CLASS	202		Information	PTS - Parktronic system																																	
C-CLASS	202		Information	NAV - Navigation module																																	
C-CLASS	202		Information	IC - Instrument cluster															V																		
C-CLASS	202		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	202		Information	AUDIO/COMAND																																	
C-CLASS	202		Information	APS - Auto pilot system																																	
C-CLASS	202		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	202		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
C-CLASS	202		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	202		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	202		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	202		Air Conditioning	HB - Heater booster																																	
C-CLASS	202		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	203		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V																	V		V		V				V
C-CLASS	203		Drive	ETC - Electronic transmission control																					V	V											
C-CLASS	203		Drive	ESM - Electronic selector module																																	
C-CLASS	203		Drive	DTR - Distronic																																	
C-CLASS	203		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	203		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	203		Chassis	BAS - Brake assist																																	
C-CLASS	203		Body	WSS - Weight sensing system																																	
C-CLASS	203		Body	UCP - Upper control panel																																	
C-CLASS	203		Body	System diagnosis																																	
C-CLASS	203		Body	SCM [MRM] - Steering column module																																	
C-CLASS	203		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	203		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	203		Body	OCP - Overhead control panel																																	
C-CLASS	203		Body	Multifunction control unit																																	
C-CLASS	203		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	203		Body	Headlamp-R - Headlamp control unit																								V									
C-CLASS	203		Body	Headlamp/Headlamp-L - Headlamp control unit																								V									
C-CLASS	203		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	203		Body	CGW - Central gateway																																	
C-CLASS	203		Body	AHE - Trailer recognition																																	
C-CLASS	203		Body	AB - Airbag																																	
C-CLASS	203		Information	TV - TV tuner																																	
C-CLASS	203		Information	SOUND - Sound system																																	
C-CLASS	203		Information	PTS - Parktronic system																																	
C-CLASS	203		Information	NAV - Navigation module																																	
C-CLASS	203		Information	MIF/UCI - Media interface																																	
C-CLASS	203		Information	IC - Instrument cluster																																	
C-CLASS	203		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	203		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	203		Information	CTEL/TEL - Cellular/Mobile telephone																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
C-CLASS	203		Information	AUDIO/COMAND																																	
C-CLASS	203		Information	AGW - Audio gateway																																	
C-CLASS	203		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	203		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	203		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	203		Seat/Door	DCM-RL - Door control module rear left																								V									
C-CLASS	203		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	203		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	203		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	203		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	204		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V												V		V	V	V				V
C-CLASS	204		Drive	ETC - Electronic transmission control																						V	V								V		
C-CLASS	204		Drive	ESM - Electronic selector module																																	
C-CLASS	204		Drive	SCR - Selective catalytic reduction																														V			
C-CLASS	204		Drive	ISM - Intelligent servo module																																	
C-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
C-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	204		Drive	DTR - Distronic																																	
C-CLASS	204		Drive	AMG DRIVE UNIT																																	
C-CLASS	204		Drive	PTCU - Common powertrain controller																																	
C-CLASS	204		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	204		Chassis	Suspension																			V														
C-CLASS	204		Chassis	ES - Electrical power steering										V								V															
C-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	204		Body	WSS - Weight sensing system																																	
C-CLASS	204		Body	SCM [MRM] - Steering column module																																	
C-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	OCP - Overhead control panel																																	
C-CLASS	204		Body	Multifunction control unit																																	
C-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	204		Body	Headlamp-R - Headlamp control unit																				V				V									
C-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																				V				V									
C-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
C-CLASS	204		Body	CGW - Central gateway																																	
C-CLASS	204		Body	AHE - Trailer recognition																																	
C-CLASS	204		Body	AB - Airbag																																	
C-CLASS	204		Information	Head-up display																																	
C-CLASS	204		Information	AVE-H - Rear audio video unit																																	
C-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
C-CLASS	204		Information	ZAN - Audio/COMAND display																																	
C-CLASS	204		Information	TV - TV tuner																																	
C-CLASS	204		Information	Sound generator for exhaust system																																	
C-CLASS	204		Information	SOUND - Sound system																																	
C-CLASS	204		Information	SGR - Radar sensors control unit																																	
C-CLASS	204		Information	360' - Camera																																	
C-CLASS	204		Information	MFK - Multifunction camera																																	
C-CLASS	204		Information	RFK - Backup camera																																	
C-CLASS	204		Information	PTS - Parktronic system																																	
C-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	204		Information	NBR-RF - Right front range radar																																	
C-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	204		Information	NBR-LF - Left front range radar																																	
C-CLASS	204		Information	NAV - Navigation module																																	
C-CLASS	204		Information	MIF/UCI - Media interface																																	
C-CLASS	204		Information	ICI - InCar Internet																																	
C-CLASS	204		Information	IC - Instrument cluster														V	V																		
C-CLASS	204		Information	DVD player																																	
C-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
C-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
C-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
C-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	204		Information	AUDIO/COMAND																																	
C-CLASS	204		Information	AMG Performance Media																																	
C-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	204		Seat/Door	HKS - Tailgate control																																	
C-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
C-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	204		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	205		Drive	SCR - Selective catalytic reduction																														V			
C-CLASS	205		Drive	SG-EM - Power electronics																																	
C-CLASS	205		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	205		Drive	HFPM - Haptic accelerator pedal module																																	
C-CLASS	205		Drive	DTR - Distronic																					V												
C-CLASS	205		Drive	ISM - Intelligent servo module																																	
C-CLASS	205		Drive	ME/CDI/CNG - Engine control unit									V		V		V													V		V	V	V			V
C-CLASS	205		Drive	ETC - Electronic transmission control																															V		
C-CLASS	205		Drive	PTCU - Common powertrain controller																																	
C-CLASS	205		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	205		Chassis	Suspension																																	
C-CLASS	205		Chassis	ABS/ESP - Electronic stability program																											V						
C-CLASS	205		Chassis	ES - Electrical power steering										V																							
C-CLASS	205		Chassis	EFB - Electric parking brake																																	
C-CLASS	205		Information	TPAD - Touchpad																																	
C-CLASS	205		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	205		Information	360' - Camera																																	
C-CLASS	205		Information	Sound generator for exhaust system																																	
C-CLASS	205		Information	SOUND - Sound system																																	
C-CLASS	205		Information	RFK - Backup camera																																	
C-CLASS	205		Information	SGR - Radar sensors control unit																					V												
C-CLASS	205		Information	PTS - Parktronic system																																	
C-CLASS	205		Information	NBR-RF - Right front range radar																																	
C-CLASS	205		Information	NBR-LF - Left front range radar																																	
C-CLASS	205		Information	MFK - Multifunction camera																																	
C-CLASS	205		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	205		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	205		Information	Head-up display																																	
C-CLASS	205		Information	AUDIO/COMAND																																	
C-CLASS	205		Information	ZAN - Audio/COMAND display																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
C-CLASS	205		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	205		Information	KAB - Camera cover																																	
C-CLASS	205		Information	IC - Instrument cluster															V																		
C-CLASS	205		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	205		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
C-CLASS	205		Body	AHE - Trailer recognition																																	
C-CLASS	205		Body	SCM [MRM] - Steering column module																																	
C-CLASS	205		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	AB - Airbag																																	
C-CLASS	205		Body	Multifunction control unit																																	
C-CLASS	205		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	205		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	205		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	205		Body	SG-AWF - Collision prevention assist																																	
C-CLASS	205		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	205		Body	BNS/BMS - Battery sensor																																	
C-CLASS	205		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	205		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	205		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	205		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	205		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	205		Seat/Door	HKS - Tailgate control																																	
C-CLASS	205		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	205		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	205		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	205		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	205		Seat/Door	RVC/VDS - Convertible roof control																																	
C-CLASS	205		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	124		Drive	PMS/HFM/LH																																	
E-CLASS	124		Drive	ETC - Electronic transmission control																																	
E-CLASS	124		Drive	ISC - Idle speed control																																	
E-CLASS	124		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	124		Body	AB - Airbag																																	
E-CLASS	210		Drive	ME/CDI/CNG - Engine control unit																																	
E-CLASS	210		Drive	ETC - Electronic transmission control																						V	V										

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
E-CLASS	210		Drive	ESM - Electronic selector module																																	
E-CLASS	210		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	210		Chassis	VP - Vacuum pump brake booster																																	
E-CLASS	210		Chassis	PSE - Pneumatic system equipment																																	
E-CLASS	210		Chassis	BAS - Brake assist																																	
E-CLASS	210		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	210		Body	OCP - Overhead control panel																																	
E-CLASS	210		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	210		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	210		Body	AB - Airbag																																	
E-CLASS	210		Information	TV - TV tuner																																	
E-CLASS	210		Information	PTS - Parktronic system																																	
E-CLASS	210		Information	NAV - Navigation module																																	
E-CLASS	210		Information	IC - Instrument cluster																V																	
E-CLASS	210		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	210		Information	AUDIO/COMAND																																	
E-CLASS	210		Information	APS - Auto pilot system																																	
E-CLASS	210		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	210		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	210		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	210		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	210		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	210		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	210		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	210		Air Conditioning	HB - Heater booster																																	
E-CLASS	210		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	211		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V																	V		V		V				V
E-CLASS	211		Drive	ETC - Electronic transmission control																						V	V										
E-CLASS	211		Drive	ESM - Electronic selector module																																	
E-CLASS	211		Drive	Natural gas control unit																																	
E-CLASS	211		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	211		Drive	DTR - Distronic																																	
E-CLASS	211		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	211		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	211		Chassis	Suspension																																	
E-CLASS	211		Chassis	SBC - Sensotronic Brake Control																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
E-CLASS	211		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	211		Body	WSS - Weight sensing system																																	
E-CLASS	211		Body	UCP - Upper control panel																																	
E-CLASS	211		Body	System diagnosis																																	
E-CLASS	211		Body	SCM [MRM] - Steering column module																																	
E-CLASS	211		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	211		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
E-CLASS	211		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	211		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	OCP - Overhead control panel																																	
E-CLASS	211		Body	Multifunction control unit																																	
E-CLASS	211		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	211		Body	LAE [LAA] - Loading floor automatically extendable																																	
E-CLASS	211		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	211		Body	Headlamp-R - Headlamp control unit																								V									
E-CLASS	211		Body	Headlamp/Headlamp-L - Headlamp control unit																								V									
E-CLASS	211		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	211		Body	CGW - Central gateway																																	
E-CLASS	211		Body	BNS/BMS - Battery sensor																																	
E-CLASS	211		Body	AHE - Trailer recognition																																	
E-CLASS	211		Body	AB - Airbag																																	
E-CLASS	211		Information	TV - TV tuner																																	
E-CLASS	211		Information	SOUND - Sound system																																	
E-CLASS	211		Information	PTS - Parktronic system																																	
E-CLASS	211		Information	MIF/UCI - Media interface																																	
E-CLASS	211		Information	IC - Instrument cluster																																	
E-CLASS	211		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	211		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	211		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	211		Information	AUDIO/COMAND																																	
E-CLASS	211		Information	ASSYST PLUS - PLUS Active Service System														V																			
E-CLASS	211		Information	ASSYST Active Service System																																	
E-CLASS	211		Information	AGW - Audio gateway																																	
E-CLASS	211		Seat/Door	REDC/RWT - Rear end door control module																																	
E-CLASS	211		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
E-CLASS	211		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	211		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	211		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	211		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	211		Seat/Door	DCM-RL - Door control module rear left																								V									
E-CLASS	211		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	211		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	211		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	211		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	207		Drive	SG-EM - Power electronics																																	
E-CLASS	207		Drive	SCR - Selective catalytic reduction																														V			
E-CLASS	207		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V												V		V	V	V			V
E-CLASS	207		Drive	ETC - Electronic transmission control																					V	V									V		
E-CLASS	207		Drive	ESM - Electronic selector module																																	
E-CLASS	207		Drive	ISM - Intelligent servo module																																	
E-CLASS	207		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	207		Drive	DTR - Distronic																																	
E-CLASS	207		Drive	DSI - Direct select interface																																	
E-CLASS	207		Drive	AMG DRIVE UNIT																																	
E-CLASS	207		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	207		Chassis	Suspension																			V														
E-CLASS	207		Chassis	ES - Electrical power steering										V								V															
E-CLASS	207		Chassis	FWGW - Chassis gateway																																	
E-CLASS	207		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	207		Body	BNS/BMS - Battery sensor																																	
E-CLASS	207		Body	WSS - Weight sensing system																																	
E-CLASS	207		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	207		Body	SCM [MRM] - Steering column module																																	
E-CLASS	207		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	207		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	207		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	207		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	207		Body	Multifunction control unit																																	
E-CLASS	207		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
E-CLASS	207		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
E-CLASS	207		Body	Headlamp-R - Headlamp control unit																				V				V									
E-CLASS	207		Body	Headlamp/Headlamp-L - Headlamp control unit																				V				V									
E-CLASS	207		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	207		Body	CGW - Central gateway																																	
E-CLASS	207		Body	AHE - Trailer recognition																																	
E-CLASS	207		Body	AB - Airbag																																	
E-CLASS	207		Information	NBR-RF - Right front range radar																																	
E-CLASS	207		Information	NBR-LF - Left front range radar																																	
E-CLASS	207		Information	AVE-H - Rear audio video unit																																	
E-CLASS	207		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	207		Information	ZAN - Audio/COMAND display																																	
E-CLASS	207		Information	TV - TV tuner																																	
E-CLASS	207		Information	SOUND - Sound system																																	
E-CLASS	207		Information	SGR - Radar sensors control unit																																	
E-CLASS	207		Information	360' - Camera																																	
E-CLASS	207		Information	MFK - Multifunction camera																																	
E-CLASS	207		Information	RFK - Backup camera																																	
E-CLASS	207		Information	PTS - Parktronic system																																	
E-CLASS	207		Information	NSA - Night View Assist																																	
E-CLASS	207		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	207		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	207		Information	NAV - Navigation module																																	
E-CLASS	207		Information	MIF/UCI - Media interface																																	
E-CLASS	207		Information	ICI - InCar Internet																																	
E-CLASS	207		Information	IC - Instrument cluster														V	V																		
E-CLASS	207		Information	DVD player																																	
E-CLASS	207		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	207		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	207		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	207		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	207		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	207		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	207		Information	AUDIO/COMAND																																	
E-CLASS	207		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	207		Seat/Door	PSD/MSC - Sliding roof control																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
E-CLASS	207		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	207		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	207		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	207		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	207		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	207		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	207		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	212		Drive	SG-EM - Power electronics																																	
E-CLASS	212		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	212		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V												V		V	V	V			V
E-CLASS	212		Drive	ETC - Electronic transmission control																					V	V								V		
E-CLASS	212		Drive	ESM - Electronic selector module																																	
E-CLASS	212		Drive	SCR - Selective catalytic reduction																														V			
E-CLASS	212		Drive	ISM - Intelligent servo module																																	
E-CLASS	212		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	212		Drive	DTR - Distronic																																	
E-CLASS	212		Drive	DSI - Direct select interface																																	
E-CLASS	212		Drive	AMG DRIVE UNIT																																	
E-CLASS	212		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	212		Chassis	Suspension																			V														
E-CLASS	212		Chassis	ES - Electrical power steering										V								V															
E-CLASS	212		Chassis	FWGW - Chassis gateway																																	
E-CLASS	212		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	212		Body	BNS/BMS - Battery sensor																																	
E-CLASS	212		Body	WSS - Weight sensing system																																	
E-CLASS	212		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	212		Body	SCM [MRM] - Steering column module																																	
E-CLASS	212		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	212		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	212		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	OCP - Overhead control panel																																	
E-CLASS	212		Body	Multifunction control unit																																	
E-CLASS	212		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
E-CLASS	212		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	212		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
E-CLASS	212		Body	Headlamp-R - Headlamp control unit																				V				V									
E-CLASS	212		Body	Headlamp/Headlamp-L - Headlamp control unit																				V				V									
E-CLASS	212		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	212		Body	CGW - Central gateway																																	
E-CLASS	212		Body	AHE - Trailer recognition																																	
E-CLASS	212		Body	AB - Airbag																																	
E-CLASS	212		Information	Head-up display																																	
E-CLASS	212		Information	AVE-H - Rear audio video unit																																	
E-CLASS	212		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	212		Information	ZAN - Audio/COMAND display																																	
E-CLASS	212		Information	TV - TV tuner																																	
E-CLASS	212		Information	SOUND - Sound system																																	
E-CLASS	212		Information	SGR - Radar sensors control unit																																	
E-CLASS	212		Information	360' - Camera																																	
E-CLASS	212		Information	MFK - Multifunction camera																																	
E-CLASS	212		Information	RFK - Backup camera																																	
E-CLASS	212		Information	PTS - Parktronic system																																	
E-CLASS	212		Information	NSA - Night View Assist																																	
E-CLASS	212		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	212		Information	NBR-RF - Right front range radar																																	
E-CLASS	212		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	212		Information	NBR-LF - Left front range radar																																	
E-CLASS	212		Information	NAV - Navigation module																																	
E-CLASS	212		Information	MIF/UCI - Media interface																																	
E-CLASS	212		Information	ICI - InCar Internet																																	
E-CLASS	212		Information	IC - Instrument cluster														V	V																		
E-CLASS	212		Information	DVD player																																	
E-CLASS	212		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	212		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	212		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	212		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	212		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	212		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	212		Information	AUDIO/COMAND																																	
E-CLASS	212		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	212		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
E-CLASS	212		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	212		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	212		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	212		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	212		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	212		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	212		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	212		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	212		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	212		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	213		Drive	SCR - Selective catalytic reduction																														V			
E-CLASS	213		Drive	DTR - Distronic																																	
E-CLASS	213		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	213		Drive	HFPM - Haptic accelerator pedal module																																	
E-CLASS	213		Drive	AMG DRIVE UNIT																																	
E-CLASS	213		Drive	PTCU - Common powertrain controller																																	
E-CLASS	213		Drive	ME/CDI/CNG - Engine control unit									V		V		V												V		V	V	V			V
E-CLASS	213		Drive	ETC - Electronic transmission control																															V		
E-CLASS	213		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	213		Chassis	AIRMATIC PLUS																																	
E-CLASS	213		Chassis	ES - Electrical power steering										V																							
E-CLASS	213		Chassis	Suspension																																	
E-CLASS	213		Chassis	ABS/ESP - Electronic stability program																											V						
E-CLASS	213		Body	MTAS - Mobile phone cradle																																	
E-CLASS	213		Body	AHE - Trailer recognition																																	
E-CLASS	213		Body	SCM [MRM] - Steering column module																																	
E-CLASS	213		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
E-CLASS	213		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
E-CLASS	213		Body	AB - Airbag																																	
E-CLASS	213		Body	OCP - Overhead control panel																																	
E-CLASS	213		Body	Multifunction control unit																																	
E-CLASS	213		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
E-CLASS	213		Body	SG-DDW - DC/DC converter control unit																																	
E-CLASS	213		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	213		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	213		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	213		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	213		Body	BNS/BMS - Battery sensor																																	
E-CLASS	213		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	213		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	213		Body	AML - Ambiance light																																	
E-CLASS	213		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	213		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	213		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
E-CLASS	213		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
E-CLASS	213		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	213		Seat/Door	HKS - Tailgate control																																	
E-CLASS	213		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	213		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	213		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	213		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	213		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	213		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	213		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	213		Information	TPAD - Touchpad																																	
E-CLASS	213		Information	Sound generator for exhaust system																																	
E-CLASS	213		Information	SOUND - Sound system																																	
E-CLASS	213		Information	RFK - Backup camera																																	
E-CLASS	213		Information	PTS - Parktronic system																																	
E-CLASS	213		Information	MFK - Multifunction camera																																	
E-CLASS	213		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	213		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	213		Information	SGR - Radar sensors control unit																					V												
E-CLASS	213		Information	IC - Instrument cluster															V																		

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
E-CLASS	213		Information	Head-up display																																	
E-CLASS	213		Information	AUDIO/COMAND																																	
E-CLASS	213		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	213		Information	ZAN - Audio/COMAND display																																	
E-CLASS	213		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	213		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	140		Drive	ASF																																	
S-CLASS	140		Drive	ERE																																	
S-CLASS	140		Drive	ME1LI																																	
S-CLASS	140		Drive	ME1RE																																	
S-CLASS	140		Drive	HFM/ME2/LH																																	
S-CLASS	140		Drive	ETC - Electronic transmission control																																	
S-CLASS	140		Drive	ISC - Idle speed control																																	
S-CLASS	140		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	140		Chassis	BAS - Brake assist																																	
S-CLASS	140		Body	PSE - Pneumatic system equipment																																	
S-CLASS	140		Body	AB - Airbag																																	
S-CLASS	140		Information	PTS - Parktronic system																																	
S-CLASS	140		Information	IC - Instrument cluster																																	
S-CLASS	140		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	220		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V																	V		V		V			V
S-CLASS	220		Drive	ETC - Electronic transmission control																						V	V										
S-CLASS	220		Drive	ESM - Electronic selector module																																	
S-CLASS	220		Drive	DTR - Distronic																																	
S-CLASS	220		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	220		Chassis	Suspension																																	
S-CLASS	220		Chassis	PSE - Pneumatic system equipment																																	
S-CLASS	220		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	220		Body	UCP - Upper control panel																																	
S-CLASS	220		Body	System diagnosis																																	
S-CLASS	220		Body	SCM [MRM] - Steering column module																																	
S-CLASS	220		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	220		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
S-CLASS	220		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	220		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	220		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
S-CLASS	220		Body	OCP - Overhead control panel																																	
S-CLASS	220		Body	Multifunction control unit																																	
S-CLASS	220		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	220		Body	HSW/LRH - Steering wheel heater																																	
S-CLASS	220		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	220		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	220		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	220		Body	CGW - Central gateway																																	
S-CLASS	220		Body	AHE - Trailer recognition																																	
S-CLASS	220		Body	AB - Airbag																																	
S-CLASS	220		Information	TV - TV tuner																																	
S-CLASS	220		Information	PTS - Parktronic system																																	
S-CLASS	220		Information	NAV - Navigation module																																	
S-CLASS	220		Information	IC - Instrument cluster																V																	
S-CLASS	220		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	220		Information	AUDIO/COMAND																																	
S-CLASS	220		Information	AGW - Audio gateway																																	
S-CLASS	220		Seat/Door	OSB-R - Multicontour backrest rear																																	
S-CLASS	220		Seat/Door	OSB-FL - Multicontour backrest front left																																	
S-CLASS	220		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	220		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	220		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	220		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	220		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	220		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	220		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	220		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	220		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	220		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	220		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	221		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V												V		V	V	V				V
S-CLASS	221		Drive	ETC - Electronic transmission control																						V	V										
S-CLASS	221		Drive	SCR - Selective catalytic reduction																														V			
S-CLASS	221		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
S-CLASS	221		Drive	HSG - Hybrid control unit																											V						
S-CLASS	221		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	221		Drive	DTR - Distronic																																	
S-CLASS	221		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	221		Chassis	Suspension																																	
S-CLASS	221		Chassis	ES - Electrical power steering																																	
S-CLASS	221		Chassis	EFB - Electric parking brake																																	
S-CLASS	221		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	221		Body	WSS - Weight sensing system																																	
S-CLASS	221		Body	UCP - Upper control panel																																	
S-CLASS	221		Body	System diagnosis																																	
S-CLASS	221		Body	SG-DDW - DC/DC converter control unit																																	
S-CLASS	221		Body	SCM [MRM] - Steering column module																																	
S-CLASS	221		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	221		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	221		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	OCP - Overhead control panel																																	
S-CLASS	221		Body	Multifunction control unit																																	
S-CLASS	221		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	221		Body	Headlamp-R - Headlamp control unit																				V				V									
S-CLASS	221		Body	Headlamp/Headlamp-L - Headlamp control unit																				V				V									
S-CLASS	221		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	221		Body	CGW - Central gateway																																	
S-CLASS	221		Body	BNS/BMS - Battery sensor																																	
S-CLASS	221		Body	AHE - Trailer recognition																																	
S-CLASS	221		Body	AB - Airbag																																	
S-CLASS	221		Information	ZAN - Audio/COMAND display																																	
S-CLASS	221		Information	VCS - Voice control																																	
S-CLASS	221		Information	TV - TV tuner																																	
S-CLASS	221		Information	Tuner - Standard tuner																																	
S-CLASS	221		Information	SOUND - Sound system																																	
S-CLASS	221		Information	SGR - Radar sensors control unit																																	
S-CLASS	221		Information	MFK - Multifunction camera																																	
S-CLASS	221		Information	RFK - Backup camera																																	
S-CLASS	221		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
S-CLASS	221		Information	NSA - Night View Assist																																	
S-CLASS	221		Information	NBR-LF - Left front range radar																																	
S-CLASS	221		Information	NAV - Navigation module																																	
S-CLASS	221		Information	MIF/UCI - Media interface																																	
S-CLASS	221		Information	ICI - InCar Internet																																	
S-CLASS	221		Information	IC - Instrument cluster																																	
S-CLASS	221		Information	DVD player																																	
S-CLASS	221		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	221		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	221		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	221		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	221		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	221		Information	AVE-H - Rear audio video unit																																	
S-CLASS	221		Information	AUDIO/COMAND																																	
S-CLASS	221		Information	ASSYST PLUS - PLUS Active Service System																																	
S-CLASS	221		Information	ASSYST Active Service System																																	
S-CLASS	221		Seat/Door	TSG-MR - Right center door control unit																																	
S-CLASS	221		Seat/Door	TSG-ML - Left center door control unit																																	
S-CLASS	221		Seat/Door	TLC/GTO - Garage door opener																																	
S-CLASS	221		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	221		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
S-CLASS	221		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
S-CLASS	221		Seat/Door	HKS - Tailgate control																																	
S-CLASS	221		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	221		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	221		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	221		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	221		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	221		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	221		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	221		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	221		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	221		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	221		Air Conditioning	HBF - Rear control panel																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
S-CLASS	221		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	217		Drive	SCR - Selective catalytic reduction																															V		
S-CLASS	217		Drive	SG-EM - Power electronics																																	
S-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	217		Drive	DTR - Distronic																																	
S-CLASS	217		Drive	ISM - Intelligent servo module																																	
S-CLASS	217		Drive	PTCU - Common powertrain controller																																	
S-CLASS	217		Drive	ME/CDI/CNG - Engine control unit									V		V		V												V		V	V	V			V
S-CLASS	217		Drive	ETC - Electronic transmission control																															V		
S-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	217		Chassis	ABS/ESP - Electronic stability program																										V							
S-CLASS	217		Chassis	ES - Electrical power steering										V																							
S-CLASS	217		Chassis	Suspension																																	
S-CLASS	217		Chassis	EFB - Electric parking brake																																	
S-CLASS	217		Information	TPAD - Touchpad																																	
S-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	217		Information	360' - Camera																																	
S-CLASS	217		Information	SOUND - Sound system																																	
S-CLASS	217		Information	RFK - Backup camera																																	
S-CLASS	217		Information	SGR - Radar sensors control unit																					V												
S-CLASS	217		Information	PTS - Parktronic system																																	
S-CLASS	217		Information	NSA - Night View Assist																																	
S-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	217		Information	NBR-RF - Right front range radar																																	
S-CLASS	217		Information	NBR-LF - Left front range radar																																	
S-CLASS	217		Information	MFK - Multifunction camera																																	
S-CLASS	217		Information	Head-up display																																	
S-CLASS	217		Information	AUDIO/COMAND																																	
S-CLASS	217		Information	ZAN - Audio/COMAND display																																	
S-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	217		Information	KAB - Camera cover																																	
S-CLASS	217		Information	IC - Instrument cluster															V																		
S-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	217		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
S-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	AB - Airbag																																	
S-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	217		Body	BNS/BMS - Battery sensor																																	
S-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	217		Seat/Door	HKS - Tailgate control																																	
S-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
S-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	222		Drive	SCR - Selective catalytic reduction																														V			
S-CLASS	222		Drive	SG-EM - Power electronics																																	
S-CLASS	222		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	222		Drive	DTR - Distronic																																	
S-CLASS	222		Drive	ISM - Intelligent servo module																																	
S-CLASS	222		Drive	PTCU - Common powertrain controller																																	
S-CLASS	222		Drive	ME/CDI/CNG - Engine control unit									V		V		V												V		V	V	V				V
S-CLASS	222		Drive	ETC - Electronic transmission control																															V		
S-CLASS	222		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	222		Chassis	ES - Electrical power steering										V																							
S-CLASS	222		Chassis	ABS/ESP - Electronic stability program																										V							
S-CLASS	222		Chassis	Suspension																																	
S-CLASS	222		Chassis	EFB - Electric parking brake																																	
S-CLASS	222		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
S-CLASS	222		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	222		Information	360' - Camera																																	
S-CLASS	222		Information	Sound generator for exhaust system																																	
S-CLASS	222		Information	SOUND - Sound system																																	
S-CLASS	222		Information	RFK - Backup camera																																	
S-CLASS	222		Information	SGR - Radar sensors control unit																					V												
S-CLASS	222		Information	PTS - Parktronic system																																	
S-CLASS	222		Information	NSA - Night View Assist																																	
S-CLASS	222		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	222		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	222		Information	NBR-RF - Right front range radar																																	
S-CLASS	222		Information	NBR-LF - Left front range radar																																	
S-CLASS	222		Information	MFK - Multifunction camera																																	
S-CLASS	222		Information	Head-up display																																	
S-CLASS	222		Information	AUDIO/COMAND																																	
S-CLASS	222		Information	AVE-H - Rear audio video unit																																	
S-CLASS	222		Information	ZAN - Audio/COMAND display																																	
S-CLASS	222		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	222		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	222		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	222		Information	KAB - Camera cover																																	
S-CLASS	222		Information	IC - Instrument cluster															V																		
S-CLASS	222		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	222		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	222		Body	AHE - Trailer recognition																																	
S-CLASS	222		Body	SCM [MRM] - Steering column module																																	
S-CLASS	222		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	AB - Airbag																																	
S-CLASS	222		Body	Multifunction control unit																																	
S-CLASS	222		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	222		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	222		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	222		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
S-CLASS	222		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	222		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
S-CLASS	222		Body	BNS/BMS - Battery sensor																																	
S-CLASS	222		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	222		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	222		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	222		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	222		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
S-CLASS	222		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
S-CLASS	222		Seat/Door	HKS - Tailgate control																																	
S-CLASS	222		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	222		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	222		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	222		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	222		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	222		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	222		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	222		Air Conditioning	AAC - Automatic air conditioning																																	
G-CLASS	461 - 38P Connector		Drive	EVE																																	
G-CLASS	461 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 38P Connector		Information	IC - Instrument cluster																																	
G-CLASS	461 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	461 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit									V		V		V												V		V	V	V			V
G-CLASS	461 - 16P Connector		Drive	ETC - Electronic transmission control																					V	V											
G-CLASS	461 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	461 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	461 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	461 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	461 - 16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
G-CLASS	461 - 16P Connector		Body	CGW - Central gateway																																	
G-CLASS	461 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 16P Connector		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
G-CLASS	461 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	461 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	461 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 38P Connector		Drive	ME/CDI/CNG - Engine control unit																																	
G-CLASS	463 - 38P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	463 - 38P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 38P Connector		Drive	CC - Cruise control																																	
G-CLASS	463 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	463 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 38P Connector		Information	IC - Instrument cluster																V																	
G-CLASS	463 - 38P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 38P Connector		Information	APS - Auto pilot system																																	
G-CLASS	463 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V												V		V	V	V			V
G-CLASS	463 - 16P Connector		Drive	ETC - Electronic transmission control						V															V	V											
G-CLASS	463 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	463 - 16P Connector		Drive	SCR - Selective catalytic reduction																														V			
G-CLASS	463 - 16P Connector		Drive	ISM - Intelligent servo module																																	
G-CLASS	463 - 16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
G-CLASS	463 - 16P Connector		Drive	DTR - Distronic																																	
G-CLASS	463 - 16P Connector		Drive	DSI - Direct select interface																																	
G-CLASS	463 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	463 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	463 - 16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
G-CLASS	463 - 16P Connector		Body	UCP - Upper control panel																																	
G-CLASS	463 - 16P Connector		Body	SCM [MRM] - Steering column module																																	
G-CLASS	463 - 16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
G-CLASS	463 - 16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
G-CLASS	463 - 16P Connector		Body	OCP - Overhead control panel																																	
G-CLASS	463 - 16P Connector		Body	Multifunction control unit																																	
G-CLASS	463 - 16P Connector		Body	HSW/LRH - Steering wheel heater																																	
G-CLASS	463 - 16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																							V										
G-CLASS	463 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	463 - 16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
G-CLASS	463 - 16P Connector		Body	AHE - Trailer recognition																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
G-CLASS	463 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 16P Connector		Information	ZAN - Audio/COMAND display																																	
G-CLASS	463 - 16P Connector		Information	TV - TV tuner																																	
G-CLASS	463 - 16P Connector		Information	SOUND - Sound system																																	
G-CLASS	463 - 16P Connector		Information	PTS - Parktronic system																																	
G-CLASS	463 - 16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NAV - Navigation module																																	
G-CLASS	463 - 16P Connector		Information	MIF/UCI - Media interface																																	
G-CLASS	463 - 16P Connector		Information	IC - Instrument cluster														V	V																		
G-CLASS	463 - 16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
G-CLASS	463 - 16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
G-CLASS	463 - 16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
G-CLASS	463 - 16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
G-CLASS	463 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	463 - 16P Connector		Seat/Door	HS - Seat heater																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RR - Door control module rear right																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RL - Door control module rear left																								V									
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FR - Door control module front right																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FL - Door control module front left																																	
G-CLASS	463 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Air Conditioning	AAC - Automatic air conditioning																																	
GLA-CLASS	156		Drive	VG - Transfer case																																	
GLA-CLASS	156		Drive	ME/CDI/CNG - Engine control unit									V		V		V												V		V	V	V			V
GLA-CLASS	156		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLA-CLASS	156		Drive	ETC - Electronic transmission control																															V		
GLA-CLASS	156		Drive	DTR - Distronic																																	
GLA-CLASS	156		Drive	DSI - Direct select interface																																	
GLA-CLASS	156		Drive	PTCU - Common powertrain controller																																	
GLA-CLASS	156		Chassis	ABS/ESP - Electronic stability program																																	
GLA-CLASS	156		Chassis	ES - Electrical power steering										V								V															
GLA-CLASS	156		Chassis	EFB - Electric parking brake																																	
GLA-CLASS	156		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
GLA-CLASS	156		Body	SG-AWF - Collision prevention assist																																	
GLA-CLASS	156		Body	SCM [MRM] - Steering column module																																	
GLA-CLASS	156		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLA-CLASS	156		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	Multifunction control unit																																	
GLA-CLASS	156		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLA-CLASS	156		Body	Headlamp/Headlamp-L - Headlamp control unit																				V													
GLA-CLASS	156		Body	EZS/EIS - Electronic ignition lock																																	
GLA-CLASS	156		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLA-CLASS	156		Body	AHE - Trailer recognition																																	
GLA-CLASS	156		Body	AB - Airbag																																	
GLA-CLASS	156		Information	Head-up display																																	
GLA-CLASS	156		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLA-CLASS	156		Information	KAB - Camera cover																																	
GLA-CLASS	156		Information	ZAN - Audio/COMAND display																																	
GLA-CLASS	156		Information	TV - TV tuner																																	
GLA-CLASS	156		Information	SOUND - Sound system																																	
GLA-CLASS	156		Information	RFK - Backup camera																																	
GLA-CLASS	156		Information	MFK - Multifunction camera																																	
GLA-CLASS	156		Information	PTS - Parktronic system																																	
GLA-CLASS	156		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLA-CLASS	156		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLA-CLASS	156		Information	NAV - Navigation module																																	
GLA-CLASS	156		Information	MIF/UCI - Media interface																																	
GLA-CLASS	156		Information	IC - Instrument cluster														V	V																		
GLA-CLASS	156		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLA-CLASS	156		Information	DAB/SDAR - Digital/Satellite radio																																	
GLA-CLASS	156		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLA-CLASS	156		Information	AUDIO/COMAND																																	
GLA-CLASS	156		Seat/Door	HKS - Tailgate control																																	
GLA-CLASS	156		Seat/Door	PSD/MSC - Sliding roof control																																	
GLA-CLASS	156		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLA-CLASS	156		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLA-CLASS	156		Seat/Door	DCM-FR - Door control module front right																																	
GLA-CLASS	156		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
GLA-CLASS	156		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLA-CLASS	156		Air Conditioning	AAC - Automatic air conditioning																																	
GLK-CLASS	204		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V												V		V	V	V				V
GLK-CLASS	204		Drive	ETC - Electronic transmission control																					V	V									V		
GLK-CLASS	204		Drive	ESM - Electronic selector module																																	
GLK-CLASS	204		Drive	SCR - Selective catalytic reduction																														V			
GLK-CLASS	204		Drive	PTCU - Common powertrain controller																																	
GLK-CLASS	204		Drive	ISM - Intelligent servo module																																	
GLK-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
GLK-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLK-CLASS	204		Drive	DTR - Distronic																																	
GLK-CLASS	204		Drive	AMG DRIVE UNIT																																	
GLK-CLASS	204		Chassis	ABS/ESP - Electronic stability program																																	
GLK-CLASS	204		Chassis	Suspension																			V														
GLK-CLASS	204		Chassis	ES - Electrical power steering										V								V															
GLK-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
GLK-CLASS	204		Body	WSS - Weight sensing system																																	
GLK-CLASS	204		Body	SCM [MRM] - Steering column module																																	
GLK-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLK-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLK-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	OCP - Overhead control panel																																	
GLK-CLASS	204		Body	Multifunction control unit																																	
GLK-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLK-CLASS	204		Body	Headlamp-R - Headlamp control unit																				V				V									
GLK-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																				V				V									
GLK-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	
GLK-CLASS	204		Body	CGW - Central gateway																																	
GLK-CLASS	204		Body	AHE - Trailer recognition																																	
GLK-CLASS	204		Body	AB - Airbag																																	
GLK-CLASS	204		Information	Head-up display																																	
GLK-CLASS	204		Information	AVE-H - Rear audio video unit																																	
GLK-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLK-CLASS	204		Information	ZAN - Audio/COMAND display																																	
GLK-CLASS	204		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
GLK-CLASS	204		Information	Sound generator for exhaust system																																	
GLK-CLASS	204		Information	SOUND - Sound system																																	
GLK-CLASS	204		Information	SGR - Radar sensors control unit																																	
GLK-CLASS	204		Information	360' - Camera																																	
GLK-CLASS	204		Information	MFK - Multifunction camera																																	
GLK-CLASS	204		Information	RFK - Backup camera																																	
GLK-CLASS	204		Information	PTS - Parktronic system																																	
GLK-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLK-CLASS	204		Information	NBR-RF - Right front range radar																																	
GLK-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLK-CLASS	204		Information	NBR-LF - Left front range radar																																	
GLK-CLASS	204		Information	NAV - Navigation module																																	
GLK-CLASS	204		Information	MIF/UCI - Media interface																																	
GLK-CLASS	204		Information	ICI - InCar Internet																																	
GLK-CLASS	204		Information	IC - Instrument cluster														V	V																		
GLK-CLASS	204		Information	DVD player																																	
GLK-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLK-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
GLK-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
GLK-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
GLK-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GLK-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLK-CLASS	204		Information	AUDIO/COMAND																																	
GLK-CLASS	204		Information	AMG Performance Media																																	
GLK-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
GLK-CLASS	204		Seat/Door	HKS - Tailgate control																																	
GLK-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLK-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLK-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
GLK-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
GLK-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
GLK-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
GLK-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLK-CLASS	204		Air Conditioning	AAC - Automatic air conditioning																																	
GLC-CLASS	253		Drive	SCR - Selective catalytic reduction																														V			
GLC-CLASS	253		Drive	SG-EM - Power electronics																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
GLC-CLASS	253		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLC-CLASS	253		Drive	DTR - Distronic																					V												
GLC-CLASS	253		Drive	ISM - Intelligent servo module																																	
GLC-CLASS	253		Drive	PTCU - Common powertrain controller																																	
GLC-CLASS	253		Drive	ME/CDI/CNG - Engine control unit									V		V		V													V		V	V	V			V
GLC-CLASS	253		Drive	ETC - Electronic transmission control																															V		
GLC-CLASS	253		Chassis	TPM - Tire pressure monitor																																	
GLC-CLASS	253		Chassis	AIRMATIC PLUS																																	
GLC-CLASS	253		Chassis	ES - Electrical power steering										V																							
GLC-CLASS	253		Chassis	Suspension																																	
GLC-CLASS	253		Chassis	ABS/ESP - Electronic stability program																											V						
GLC-CLASS	253		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLC-CLASS	253		Body	AHE - Trailer recognition																																	
GLC-CLASS	253		Body	SCM [MRM] - Steering column module																																	
GLC-CLASS	253		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	AB - Airbag																																	
GLC-CLASS	253		Body	Multifunction control unit																																	
GLC-CLASS	253		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLC-CLASS	253		Body	Headlamp-R - Headlamp control unit																																	
GLC-CLASS	253		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLC-CLASS	253		Body	SG-AWF - Collision prevention assist																																	
GLC-CLASS	253		Body	EZS/EIS - Electronic ignition lock																																	
GLC-CLASS	253		Body	BNS/BMS - Battery sensor																																	
GLC-CLASS	253		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLC-CLASS	253		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLC-CLASS	253		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLC-CLASS	253		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLC-CLASS	253		Seat/Door	PSD/MSC - Sliding roof control																																	
GLC-CLASS	253		Seat/Door	HKS - Tailgate control																																	
GLC-CLASS	253		Seat/Door	DCM-RR - Door control module rear right																																	
GLC-CLASS	253		Seat/Door	DCM-RL - Door control module rear left																																	
GLC-CLASS	253		Seat/Door	DCM-FR - Door control module front right																																	
GLC-CLASS	253		Seat/Door	DCM-FL - Door control module front left																																	
GLC-CLASS	253		Information	TPAD - Touchpad																																	
GLC-CLASS	253		Information	DAB/SDAR - Digital/Satellite radio																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
GLC-CLASS	253		Information	360' - Camera																																	
GLC-CLASS	253		Information	Sound generator for exhaust system																																	
GLC-CLASS	253		Information	SOUND - Sound system																																	
GLC-CLASS	253		Information	RFK - Backup camera																																	
GLC-CLASS	253		Information	SGR - Radar sensors control unit																					V												
GLC-CLASS	253		Information	PTS - Parktronic system																																	
GLC-CLASS	253		Information	NBR-RF - Right front range radar																																	
GLC-CLASS	253		Information	NBR-LF - Left front range radar																																	
GLC-CLASS	253		Information	MFK - Multifunction camera																																	
GLC-CLASS	253		Information	IC - Instrument cluster															V																		
GLC-CLASS	253		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLC-CLASS	253		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLC-CLASS	253		Information	Head-up display																																	
GLC-CLASS	253		Information	AUDIO/COMAND																																	
GLC-CLASS	253		Information	SG-MSND - Engine sound																																	
GLC-CLASS	253		Information	ZAN - Audio/COMAND display																																	
GLC-CLASS	253		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLC-CLASS	253		Information	KAB - Camera cover																																	
GLC-CLASS	253		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLC-CLASS	253		Information	AMG Performance Media																																	
GLC-CLASS	253		Air Conditioning	AAC - Automatic air conditioning																																	
GLE-CLASS	292		Drive	SCR - Selective catalytic reduction																														V			
GLE-CLASS	292		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLE-CLASS	292		Drive	ISM - Intelligent servo module																																	
GLE-CLASS	292		Drive	DTR - Distronic																																	
GLE-CLASS	292		Drive	ME/CDI/CNG - Engine control unit									V		V		V												V		V	V	V			V
GLE-CLASS	292		Drive	ETC - Electronic transmission control																						V	V								V	
GLE-CLASS	292		Chassis	TPM - Tire pressure monitor																																	
GLE-CLASS	292		Chassis	FWGW - Chassis gateway																																	
GLE-CLASS	292		Chassis	ABS/ESP - Electronic stability program																																	
GLE-CLASS	292		Chassis	ES - Electrical power steering										V								V															
GLE-CLASS	292		Chassis	EFB - Electric parking brake																																	
GLE-CLASS	292		Chassis	Suspension																			V														
GLE-CLASS	292		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLE-CLASS	292		Body	AHE - Trailer recognition																																	
GLE-CLASS	292		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
GLE-CLASS	292		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLE-CLASS	292		Body	AB - Airbag																																	
GLE-CLASS	292		Body	Multifunction control unit																																	
GLE-CLASS	292		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLE-CLASS	292		Body	Headlamp-R - Headlamp control unit																				V													
GLE-CLASS	292		Body	Headlamp/Headlamp-L - Headlamp control unit																				V													
GLE-CLASS	292		Body	SG-AWF - Collision prevention assist																																	
GLE-CLASS	292		Body	EZS/EIS - Electronic ignition lock																																	
GLE-CLASS	292		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLE-CLASS	292		Information	TPAD - Touchpad																																	
GLE-CLASS	292		Information	DAB/SDAR - Digital/Satellite radio																																	
GLE-CLASS	292		Information	360' - Camera																																	
GLE-CLASS	292		Information	SOUND - Sound system																																	
GLE-CLASS	292		Information	RFK - Backup camera																																	
GLE-CLASS	292		Information	SGR - Radar sensors control unit																																	
GLE-CLASS	292		Information	PTS - Parktronic system																																	
GLE-CLASS	292		Information	MFK - Multifunction camera																																	
GLE-CLASS	292		Information	NBR-RF - Right front range radar																																	
GLE-CLASS	292		Information	NBR-LF - Left front range radar																																	
GLE-CLASS	292		Information	IC - Instrument cluster														V	V																		
GLE-CLASS	292		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLE-CLASS	292		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLE-CLASS	292		Information	Head-up display																																	
GLE-CLASS	292		Information	AUDIO/COMAND																																	
GLE-CLASS	292		Information	AVE-H - Rear audio video unit																																	
GLE-CLASS	292		Information	DVD player																																	
GLE-CLASS	292		Information	SG-MSND - Engine sound																																	
GLE-CLASS	292		Information	ZAN - Audio/COMAND display																																	
GLE-CLASS	292		Information	D-FOR - Display in right rear passenger																																	
GLE-CLASS	292		Information	D-FOL - Display in left rear passenger																																	
GLE-CLASS	292		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLE-CLASS	292		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLE-CLASS	292		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLE-CLASS	292		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
GLE-CLASS	292		Seat/Door	PSD/MSC - Sliding roof control																																	
GLE-CLASS	292		Seat/Door	HKS - Tailgate control																																	
GLE-CLASS	292		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DCM-RR - Door control module rear right																																	
GLE-CLASS	292		Seat/Door	DCM-RL - Door control module rear left																																	
GLE-CLASS	292		Seat/Door	DCM-FR - Door control module front right																																	
GLE-CLASS	292		Seat/Door	DCM-FL - Door control module front left																																	
GLE-CLASS	292		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLE-CLASS	292		Air Conditioning	HBF - Rear control panel																																	
GLE-CLASS	292		Air Conditioning	AAC - Automatic air conditioning																																	
GL-CLASS	164		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V												V		V	V	V				V
GL-CLASS	164		Drive	ETC - Electronic transmission control																						V	V								V		
GL-CLASS	164		Drive	VG - Transfer case																																	
GL-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
GL-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
GL-CLASS	164		Drive	SCR - Selective catalytic reduction																														V			
GL-CLASS	164		Drive	ISM - Intelligent servo module																																	
GL-CLASS	164		Drive	HSG - Hybrid control unit																										V							
GL-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
GL-CLASS	164		Drive	DTR - Distronic																																	
GL-CLASS	164		Chassis	ABS/ESP - Electronic stability program																																	
GL-CLASS	164		Chassis	Suspension																																	
GL-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
GL-CLASS	164		Chassis	ES - Electrical power steering																																	
GL-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	164		Body	WSS - Weight sensing system																																	
GL-CLASS	164		Body	UCP - Upper control panel																																	
GL-CLASS	164		Body	System diagnosis																																	
GL-CLASS	164		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GL-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
GL-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
GL-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	164		Body	Headlamp-R - Headlamp control unit																								V									
GL-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																								V									
GL-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	164		Body	CGW - Central gateway																																	
GL-CLASS	164		Body	AB - Airbag																																	
GL-CLASS	164		Information	TV - TV tuner																																	
GL-CLASS	164		Information	SOUND - Sound system																																	
GL-CLASS	164		Information	RFK - Backup camera																	V																
GL-CLASS	164		Information	PTS - Parktronic system																																	
GL-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	164		Information	NAV - Navigation module																																	
GL-CLASS	164		Information	MIF/UCI - Media interface																																	
GL-CLASS	164		Information	IC - Instrument cluster																																	
GL-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GL-CLASS	164		Information	CM - Compass module																																	
GL-CLASS	164		Information	AVE-H - Rear audio video unit																																	
GL-CLASS	164		Information	AUDIO/COMAND																																	
GL-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System														V																			
GL-CLASS	164		Information	ASSYST Active Service System																																	
GL-CLASS	164		Information	AGW - Audio gateway																																	
GL-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
GL-CLASS	164		Seat/Door	HS - Seat heater																																	
GL-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
GL-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
GL-CLASS	164		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GL-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
GL-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
GL-CLASS	166		Drive	SG-EM - Power electronics																																	
GL-CLASS	166		Drive	PTCU - Common powertrain controller																																	
GL-CLASS	166		Drive	ME/CDI/CNG - Engine control unit									V		V		V												V		V	V	V			V
GL-CLASS	166		Drive	ETC - Electronic transmission control																					V	V									V	
GL-CLASS	166		Drive	VG - Transfer case																																	
GL-CLASS	166		Drive	SCR - Selective catalytic reduction																														V			
GL-CLASS	166		Drive	ISM - Intelligent servo module																																	
GL-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	166		Drive	DTR - Distronic																																	
GL-CLASS	166		Chassis	ABS/ESP - Electronic stability program																																	
GL-CLASS	166		Chassis	Suspension																			V														
GL-CLASS	166		Chassis	ES - Electrical power steering										V								V															
GL-CLASS	166		Chassis	EFB - Electric parking brake																																	
GL-CLASS	166		Chassis	FWGW - Chassis gateway																																	
GL-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
GL-CLASS	166		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GL-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	Multifunction control unit																																	
GL-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	166		Body	Headlamp-R - Headlamp control unit																				V													
GL-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																				V													
GL-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GL-CLASS	166		Body	AHE - Trailer recognition																																	
GL-CLASS	166		Body	AB - Airbag																																	
GL-CLASS	166		Information	Sound generator for exhaust system																																	
GL-CLASS	166		Information	Head-up display																																	
GL-CLASS	166		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
GL-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GL-CLASS	166		Information	ZAN - Audio/COMAND display																																	
GL-CLASS	166		Information	TV - TV tuner																																	
GL-CLASS	166		Information	SOUND - Sound system																																	
GL-CLASS	166		Information	SGR - Radar sensors control unit																																	
GL-CLASS	166		Information	360' - Camera																																	
GL-CLASS	166		Information	RFK - Backup camera																																	
GL-CLASS	166		Information	MFK - Multifunction camera																																	
GL-CLASS	166		Information	PTS - Parktronic system																																	
GL-CLASS	166		Information	NSA - Night View Assist																																	
GL-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	166		Information	NBR-RF - Right front range radar																																	
GL-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	166		Information	NBR-LF - Left front range radar																																	
GL-CLASS	166		Information	NAV - Navigation module																																	
GL-CLASS	166		Information	MIF/UCI - Media interface																																	
GL-CLASS	166		Information	IC - Instrument cluster														V	V																		
GL-CLASS	166		Information	DVD player																																	
GL-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GL-CLASS	166		Information	AUDIO/COMAND																																	
GL-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
GL-CLASS	166		Seat/Door	HKS - Tailgate control																																	
GL-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
GL-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
GL-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
GL-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
GL-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
GL-CLASS	166		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	163		Drive	ME/CDI/CNG - Engine control unit																																	
M-CLASS	163		Drive	ETC - Electronic transmission control																						V	V										
M-CLASS	163		Drive	ESM - Electronic selector module																																	
M-CLASS	163		Drive	VG - Transfer case																																	
M-CLASS	163		Chassis	ABS/ESP - Electronic stability program																																	
M-CLASS	163		Chassis	VP - Vacuum pump brake booster																																	
M-CLASS	163		Chassis	BAS - Brake assist																																	
M-CLASS	163		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	163		Body	AB - Airbag																																	
M-CLASS	163		Body	AAM - All activity module																																	
M-CLASS	163		Information	PTS - Parktronic system																																	
M-CLASS	163		Information	IC - Instrument cluster																V																	
M-CLASS	163		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	163		Information	AUDIO/COMAND																																	
M-CLASS	163		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	163		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V												V		V	V	V				V
M-CLASS	164		Drive	ETC - Electronic transmission control																						V	V								V		
M-CLASS	164		Drive	VG - Transfer case																																	
M-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
M-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
M-CLASS	164		Drive	SCR - Selective catalytic reduction																														V			
M-CLASS	164		Drive	ISM - Intelligent servo module																																	
M-CLASS	164		Drive	HSG - Hybrid control unit																										V							
M-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
M-CLASS	164		Drive	DTR - Distronic																																	
M-CLASS	164		Chassis	ABS/ESP - Electronic stability program																																	
M-CLASS	164		Chassis	Suspension																																	
M-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
M-CLASS	164		Chassis	ES - Electrical power steering																																	
M-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	164		Body	WSS - Weight sensing system																																	
M-CLASS	164		Body	UCP - Upper control panel																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
M-CLASS	164		Body	System diagnosis																																	
M-CLASS	164		Body	SCM [MRM] - Steering column module																																	
M-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
M-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	OCP - Overhead control panel																																	
M-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
M-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	164		Body	Headlamp-R - Headlamp control unit																							V										
M-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																							V										
M-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	164		Body	CGW - Central gateway																																	
M-CLASS	164		Body	AB - Airbag																																	
M-CLASS	164		Information	TV - TV tuner																																	
M-CLASS	164		Information	SOUND - Sound system																																	
M-CLASS	164		Information	RFK - Backup camera																	V																
M-CLASS	164		Information	PTS - Parktronic system																																	
M-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	164		Information	NAV - Navigation module																																	
M-CLASS	164		Information	MIF/UCI - Media interface																																	
M-CLASS	164		Information	IC - Instrument cluster																																	
M-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
M-CLASS	164		Information	CM - Compass module																																	
M-CLASS	164		Information	AVE-H - Rear audio video unit																																	
M-CLASS	164		Information	AUDIO/COMAND																																	
M-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System														V																			
M-CLASS	164		Information	ASSYST Active Service System																																	
M-CLASS	164		Information	AGW - Audio gateway																																	
M-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
M-CLASS	164		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
M-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
M-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	164		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
M-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	166		Drive	SG-EM - Power electronics																																	
M-CLASS	166		Drive	ME/CDI/CNG - Engine control unit									V		V		V												V		V	V	V			V
M-CLASS	166		Drive	ETC - Electronic transmission control																					V	V									V		
M-CLASS	166		Drive	VG - Transfer case																																	
M-CLASS	166		Drive	SCR - Selective catalytic reduction																														V			
M-CLASS	166		Drive	PTCU - Common powertrain controller																																	
M-CLASS	166		Drive	ISM - Intelligent servo module																																	
M-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	166		Drive	DTR - Distronic																																	
M-CLASS	166		Chassis	ABS/ESP - Electronic stability program																																	
M-CLASS	166		Chassis	Suspension																			V														
M-CLASS	166		Chassis	ES - Electrical power steering										V								V															
M-CLASS	166		Chassis	EFB - Electric parking brake																																	
M-CLASS	166		Chassis	FWGW - Chassis gateway																																	
M-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
M-CLASS	166		Body	SCM [MRM] - Steering column module																																	
M-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
M-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	Multifunction control unit																																	
M-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	166		Body	Headlamp-R - Headlamp control unit																				V													
M-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																				V													

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
M-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
M-CLASS	166		Body	AHE - Trailer recognition																																	
M-CLASS	166		Body	AB - Airbag																																	
M-CLASS	166		Information	Sound generator for exhaust system																																	
M-CLASS	166		Information	Head-up display																																	
M-CLASS	166		Information	AVE-H - Rear audio video unit																																	
M-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
M-CLASS	166		Information	ZAN - Audio/COMAND display																																	
M-CLASS	166		Information	TV - TV tuner																																	
M-CLASS	166		Information	SOUND - Sound system																																	
M-CLASS	166		Information	SGR - Radar sensors control unit																																	
M-CLASS	166		Information	360' - Camera																																	
M-CLASS	166		Information	RFK - Backup camera																																	
M-CLASS	166		Information	MFK - Multifunction camera																																	
M-CLASS	166		Information	PTS - Parktronic system																																	
M-CLASS	166		Information	NSA - Night View Assist																																	
M-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	166		Information	NBR-RF - Right front range radar																																	
M-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	166		Information	NBR-LF - Left front range radar																																	
M-CLASS	166		Information	NAV - Navigation module																																	
M-CLASS	166		Information	MIF/UCI - Media interface																																	
M-CLASS	166		Information	IC - Instrument cluster														V	V																		
M-CLASS	166		Information	DVD player																																	
M-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
M-CLASS	166		Information	AUDIO/COMAND																																	
M-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
M-CLASS	166		Seat/Door	HKS - Tailgate control																																	
M-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
M-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
M-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
M-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
M-CLASS	166		Air Conditioning	AAC - Automatic air conditioning																																	
R-CLASS	251		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V												V		V	V	V				V
R-CLASS	251		Drive	ETC - Electronic transmission control																					V	V											
R-CLASS	251		Drive	SCR - Selective catalytic reduction																														V			
R-CLASS	251		Drive	ISM - Intelligent servo module																																	
R-CLASS	251		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
R-CLASS	251		Drive	DTR - Distronic																																	
R-CLASS	251		Chassis	ABS/ESP - Electronic stability program																																	
R-CLASS	251		Chassis	Suspension																																	
R-CLASS	251		Chassis	ES - Electrical power steering																																	
R-CLASS	251		Chassis	TPM - Tire pressure monitor																																	
R-CLASS	251		Body	WSS - Weight sensing system																																	
R-CLASS	251		Body	UCP - Upper control panel																																	
R-CLASS	251		Body	System diagnosis																																	
R-CLASS	251		Body	SCM [MRM] - Steering column module																																	
R-CLASS	251		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
R-CLASS	251		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
R-CLASS	251		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	OCP - Overhead control panel																																	
R-CLASS	251		Body	LCP/HBF - Lower/Rear control panel																																	
R-CLASS	251		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
R-CLASS	251		Body	Headlamp-R - Headlamp control unit																			V														
R-CLASS	251		Body	Headlamp/Headlamp-L - Headlamp control unit																			V														
R-CLASS	251		Body	EZS/EIS - Electronic ignition lock																																	
R-CLASS	251		Body	CGW - Central gateway																																	
R-CLASS	251		Body	AB - Airbag																																	
R-CLASS	251		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
R-CLASS	251		Information	SOUND - Sound system																																	
R-CLASS	251		Information	RFK - Backup camera																	V																
R-CLASS	251		Information	PTS - Parktronic system																																	
R-CLASS	251		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
R-CLASS	251		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
R-CLASS	251		Information	NAV - Navigation module																																	
R-CLASS	251		Information	MIF/UCI - Media interface																																	
R-CLASS	251		Information	IC - Instrument cluster																																	
R-CLASS	251		Information	DTA - Mbrace or TELEAID/GPS Box																																	
R-CLASS	251		Information	D-FOR - Display in right rear passenger																																	
R-CLASS	251		Information	D-FOL - Display in left rear passenger																																	
R-CLASS	251		Information	DAB/SDAR - Digital/Satellite radio																																	
R-CLASS	251		Information	CTEL/TEL - Cellular/Mobile telephone																																	
R-CLASS	251		Information	CM - Compass module																																	
R-CLASS	251		Information	AVE-H - Rear audio video unit																																	
R-CLASS	251		Information	AUDIO/COMAND																																	
R-CLASS	251		Information	ASSYST PLUS - PLUS Active Service System														V																			
R-CLASS	251		Information	ASSYST Active Service System																																	
R-CLASS	251		Information	AGW - Audio gateway																																	
R-CLASS	251		Seat/Door	REDC/RWT - Rear end door control module																																	
R-CLASS	251		Seat/Door	HS - Seat heater																																	
R-CLASS	251		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
R-CLASS	251		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
R-CLASS	251		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
R-CLASS	251		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DCM-FR - Door control module front right																																	
R-CLASS	251		Seat/Door	DCM-FL - Door control module front left																																	
R-CLASS	251		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
R-CLASS	251		Air Conditioning	AAC - Automatic air conditioning																																	
CLA-CLASS	117		Drive	VG - Transfer case																																	
CLA-CLASS	117		Drive	ME/CDI/CNG - Engine control unit									V		V		V												V		V	V	V			V
CLA-CLASS	117		Drive	ETC - Electronic transmission control																															V		
CLA-CLASS	117		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLA-CLASS	117		Drive	DTR - Distronic																																	
CLA-CLASS	117		Drive	DSI - Direct select interface																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
CLA-CLASS	117		Drive	PTCU - Common powertrain controller																																	
CLA-CLASS	117		Chassis	ABS/ESP - Electronic stability program																																	
CLA-CLASS	117		Chassis	ES - Electrical power steering										V								V															
CLA-CLASS	117		Chassis	EFB - Electric parking brake																																	
CLA-CLASS	117		Chassis	TPM - Tire pressure monitor																																	
CLA-CLASS	117		Body	SG-AWF - Collision prevention assist																																	
CLA-CLASS	117		Body	SCM [MRM] - Steering column module																																	
CLA-CLASS	117		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLA-CLASS	117		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	Multifunction control unit																																	
CLA-CLASS	117		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLA-CLASS	117		Body	Headlamp/Headlamp-L - Headlamp control unit																				V													
CLA-CLASS	117		Body	EZS/EIS - Electronic ignition lock																																	
CLA-CLASS	117		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CLA-CLASS	117		Body	AHE - Trailer recognition																																	
CLA-CLASS	117		Body	AB - Airbag																																	
CLA-CLASS	117		Information	Head-up display																																	
CLA-CLASS	117		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLA-CLASS	117		Information	KAB - Camera cover																																	
CLA-CLASS	117		Information	ZAN - Audio/COMAND display																																	
CLA-CLASS	117		Information	TV - TV tuner																																	
CLA-CLASS	117		Information	SOUND - Sound system																																	
CLA-CLASS	117		Information	RFK - Backup camera																																	
CLA-CLASS	117		Information	MFK - Multifunction camera																																	
CLA-CLASS	117		Information	PTS - Parktronic system																																	
CLA-CLASS	117		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLA-CLASS	117		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLA-CLASS	117		Information	NAV - Navigation module																																	
CLA-CLASS	117		Information	MIF/UCI - Media interface																																	
CLA-CLASS	117		Information	IC - Instrument cluster														V	V																		
CLA-CLASS	117		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLA-CLASS	117		Information	DAB/SDAR - Digital/Satellite radio																																	
CLA-CLASS	117		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLA-CLASS	117		Information	AUDIO/COMAND																																	
CLA-CLASS	117		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
CLA-CLASS	117		Seat/Door	PSD/MSC - Sliding roof control																																	
CLA-CLASS	117		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLA-CLASS	117		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLA-CLASS	117		Seat/Door	DCM-FR - Door control module front right																																	
CLA-CLASS	117		Seat/Door	DCM-FL - Door control module front left																																	
CLA-CLASS	117		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLA-CLASS	117		Air Conditioning	AAC - Automatic air conditioning																																	
CLK-CLASS	208		Drive	ME/CDI/CNG - Engine control unit																																	
CLK-CLASS	208		Drive	ETC - Electronic transmission control																						V	V										
CLK-CLASS	208		Drive	ESM - Electronic selector module																																	
CLK-CLASS	208		Chassis	PSE - Pneumatic system equipment																																	
CLK-CLASS	208		Chassis	ABS/ESP - Electronic stability program																																	
CLK-CLASS	208		Chassis	VP - Vacuum pump brake booster																																	
CLK-CLASS	208		Chassis	BAS - Brake assist																																	
CLK-CLASS	208		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	208		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	208		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	208		Body	OCP - Overhead control panel																																	
CLK-CLASS	208		Body	AB - Airbag																																	
CLK-CLASS	208		Information	TV - TV tuner																																	
CLK-CLASS	208		Information	PTS - Parktronic system																																	
CLK-CLASS	208		Information	NAV - Navigation module																																	
CLK-CLASS	208		Information	IC - Instrument cluster																V																	
CLK-CLASS	208		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	208		Information	AUDIO/COMAND																																	
CLK-CLASS	208		Information	APS - Auto pilot system																																	
CLK-CLASS	208		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	208		Air Conditioning	AAC - Automatic air conditioning																																	
CLK-CLASS	208		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	208		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	208		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	208		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V																	V		V		V			V
CLK-CLASS	209		Drive	ETC - Electronic transmission control																						V	V										
CLK-CLASS	209		Drive	ESM - Electronic selector module																																	
CLK-CLASS	209		Drive	DTR - Distronic																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
CLK-CLASS	209		Chassis	ABS/ESP - Electronic stability program																																	
CLK-CLASS	209		Chassis	TPM - Tire pressure monitor																																	
CLK-CLASS	209		Body	WSS - Weight sensing system																																	
CLK-CLASS	209		Body	UCP - Upper control panel																																	
CLK-CLASS	209		Body	SCM [MRM] - Steering column module																																	
CLK-CLASS	209		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLK-CLASS	209		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	209		Body	RCM - Rear control module																																	
CLK-CLASS	209		Body	OCP - Overhead control panel																																	
CLK-CLASS	209		Body	Multifunction control unit																																	
CLK-CLASS	209		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	209		Body	Headlamp-R - Headlamp control unit																																	
CLK-CLASS	209		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLK-CLASS	209		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	209		Body	BNS/BMS - Battery sensor																																	
CLK-CLASS	209		Body	AHE - Trailer recognition																																	
CLK-CLASS	209		Body	AB - Airbag																																	
CLK-CLASS	209		Information	TV - TV tuner																																	
CLK-CLASS	209		Information	PTS - Parktronic system																																	
CLK-CLASS	209		Information	NAV - Navigation module																																	
CLK-CLASS	209		Information	IC - Instrument cluster																																	
CLK-CLASS	209		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	209		Information	AUDIO/COMAND																																	
CLK-CLASS	209		Information	AGW - Audio gateway																																	
CLK-CLASS	209		Seat/Door	RVC/VDS - Convertible roof control																																	
CLK-CLASS	209		Seat/Door	REDC/RWT - Rear end door control module																																	
CLK-CLASS	209		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	209		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	209		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	209		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	209		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	219		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V																	V		V		V			V
CLS-CLASS	219		Drive	ETC - Electronic transmission control																					V	V											
CLS-CLASS	219		Drive	ESM - Electronic selector module																																	
CLS-CLASS	219		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
CLS-CLASS	219		Drive	DTR - Distronic																																	
CLS-CLASS	219		Chassis	ABS/ESP - Electronic stability program																																	
CLS-CLASS	219		Chassis	Suspension																																	
CLS-CLASS	219		Chassis	SBC - Sensotronic Brake Control																																	
CLS-CLASS	219		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	219		Body	WSS - Weight sensing system																																	
CLS-CLASS	219		Body	UCP - Upper control panel																																	
CLS-CLASS	219		Body	System diagnosis																																	
CLS-CLASS	219		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	219		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	219		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CLS-CLASS	219		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLS-CLASS	219		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	OCP - Overhead control panel																																	
CLS-CLASS	219		Body	LCP/HBF - Lower/Rear control panel																																	
CLS-CLASS	219		Body	LAE [LAA] - Loading floor automatically extendable																																	
CLS-CLASS	219		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	219		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	219		Body	CGW - Central gateway																																	
CLS-CLASS	219		Body	BNS/BMS - Battery sensor																																	
CLS-CLASS	219		Body	AB - Airbag																																	
CLS-CLASS	219		Information	TV - TV tuner																																	
CLS-CLASS	219		Information	SOUND - Sound system																																	
CLS-CLASS	219		Information	PTS - Parktronic system																																	
CLS-CLASS	219		Information	MIF/UCI - Media interface																																	
CLS-CLASS	219		Information	IC - Instrument cluster																																	
CLS-CLASS	219		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	219		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	219		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	219		Information	AUDIO/COMAND																																	
CLS-CLASS	219		Information	ASSYST PLUS - PLUS Active Service System														V																			
CLS-CLASS	219		Information	ASSYST Active Service System																																	
CLS-CLASS	219		Information	AGW - Audio gateway																																	
CLS-CLASS	219		Seat/Door	REDC/RWT - Rear end door control module																																	
CLS-CLASS	219		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
CLS-CLASS	219		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	219		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	219		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	219		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	219		Seat/Door	DCM-RL - Door control module rear left																								V									
CLS-CLASS	219		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	219		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	219		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	219		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	218		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V												V		V	V	V			V
CLS-CLASS	218		Drive	ETC - Electronic transmission control																					V	V								V		
CLS-CLASS	218		Drive	ESM - Electronic selector module																																	
CLS-CLASS	218		Drive	SCR - Selective catalytic reduction																														V			
CLS-CLASS	218		Drive	ISM - Intelligent servo module																																	
CLS-CLASS	218		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLS-CLASS	218		Drive	DTR - Distronic																																	
CLS-CLASS	218		Drive	DSI - Direct select interface																																	
CLS-CLASS	218		Drive	AMG DRIVE UNIT																																	
CLS-CLASS	218		Chassis	ABS/ESP - Electronic stability program																																	
CLS-CLASS	218		Chassis	Suspension																			V														
CLS-CLASS	218		Chassis	ES - Electrical power steering										V								V															
CLS-CLASS	218		Chassis	FWGW - Chassis gateway																																	
CLS-CLASS	218		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	218		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
CLS-CLASS	218		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
CLS-CLASS	218		Body	WSS - Weight sensing system																																	
CLS-CLASS	218		Body	SG-AWF - Collision prevention assist																																	
CLS-CLASS	218		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	218		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	218		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLS-CLASS	218		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	OCP - Overhead control panel																																	
CLS-CLASS	218		Body	Multifunction control unit																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
CLS-CLASS	218		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLS-CLASS	218		Body	HSW/LRH - Steering wheel heater																																	
CLS-CLASS	218		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
CLS-CLASS	218		Body	Headlamp-R - Headlamp control unit																				V													
CLS-CLASS	218		Body	Headlamp/Headlamp-L - Headlamp control unit																				V													
CLS-CLASS	218		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	218		Body	CGW - Central gateway																																	
CLS-CLASS	218		Body	AHE - Trailer recognition																																	
CLS-CLASS	218		Body	AB - Airbag																																	
CLS-CLASS	218		Information	360' - Camera																																	
CLS-CLASS	218		Information	AVE-H - Rear audio video unit																																	
CLS-CLASS	218		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLS-CLASS	218		Information	ZAN - Audio/COMAND display																																	
CLS-CLASS	218		Information	TV - TV tuner																																	
CLS-CLASS	218		Information	SOUND - Sound system																																	
CLS-CLASS	218		Information	SGR - Radar sensors control unit																																	
CLS-CLASS	218		Information	MFK - Multifunction camera																																	
CLS-CLASS	218		Information	RFK - Backup camera																																	
CLS-CLASS	218		Information	PTS - Parktronic system																																	
CLS-CLASS	218		Information	NSA - Night View Assist																																	
CLS-CLASS	218		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLS-CLASS	218		Information	NBR-RF - Right front range radar																																	
CLS-CLASS	218		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLS-CLASS	218		Information	NBR-LF - Left front range radar																																	
CLS-CLASS	218		Information	NAV - Navigation module																																	
CLS-CLASS	218		Information	MIF/UCI - Media interface																																	
CLS-CLASS	218		Information	ICI - InCar Internet																																	
CLS-CLASS	218		Information	IC - Instrument cluster														V	V																		
CLS-CLASS	218		Information	DVD player																																	
CLS-CLASS	218		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	218		Information	D-FOR - Display in right rear passenger																																	
CLS-CLASS	218		Information	D-FOL - Display in left rear passenger																																	
CLS-CLASS	218		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	218		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	218		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLS-CLASS	218		Information	AUDIO/COMAND																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
CLS-CLASS	218		Seat/Door	PSD/MSC - Sliding roof control																																	
CLS-CLASS	218		Seat/Door	HKS - Tailgate control																																	
CLS-CLASS	218		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	218		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	218		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	218		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	218		Seat/Door	DCM-RL - Door control module rear left																																	
CLS-CLASS	218		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	218		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	218		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	218		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	215		Drive	ME/CDI/CNG - Engine control unit																																	
CL-CLASS	215		Drive	ETC - Electronic transmission control																						V	V										
CL-CLASS	215		Drive	ESM - Electronic selector module																																	
CL-CLASS	215		Drive	DTR - Distronic																																	
CL-CLASS	215		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	215		Chassis	Suspension																																	
CL-CLASS	215		Chassis	PSE - Pneumatic system equipment																																	
CL-CLASS	215		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	215		Body	UCP - Upper control panel																																	
CL-CLASS	215		Body	System diagnosis																																	
CL-CLASS	215		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	215		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	215		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CL-CLASS	215		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	215		Body	RCM - Rear control module																																	
CL-CLASS	215		Body	OCP - Overhead control panel																																	
CL-CLASS	215		Body	Multifunction control unit																																	
CL-CLASS	215		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	215		Body	HSW/LRH - Steering wheel heater																																	
CL-CLASS	215		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	215		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	215		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	215		Body	CGW - Central gateway																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
CL-CLASS	215		Body	AHE - Trailer recognition																																	
CL-CLASS	215		Body	AB - Airbag																																	
CL-CLASS	215		Information	TV - TV tuner																																	
CL-CLASS	215		Information	PTS - Parktronic system																																	
CL-CLASS	215		Information	NAV - Navigation module																																	
CL-CLASS	215		Information	IC - Instrument cluster																V																	
CL-CLASS	215		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	215		Information	AUDIO/COMAND																																	
CL-CLASS	215		Information	AGW - Audio gateway																																	
CL-CLASS	215		Seat/Door	OSB-FR - Multicontour backrest front right																																	
CL-CLASS	215		Seat/Door	OSB-FL - Multicontour backrest front left																																	
CL-CLASS	215		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	215		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	215		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	215		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	215		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	215		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
CL-CLASS	215		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	216		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V												V		V	V	V				V
CL-CLASS	216		Drive	ETC - Electronic transmission control																						V	V										
CL-CLASS	216		Drive	ISM - Intelligent servo module																																	
CL-CLASS	216		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	216		Drive	DTR - Distronic																																	
CL-CLASS	216		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	216		Chassis	Suspension																																	
CL-CLASS	216		Chassis	ES - Electrical power steering																																	
CL-CLASS	216		Chassis	EFB - Electric parking brake																																	
CL-CLASS	216		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	216		Body	WSS - Weight sensing system																																	
CL-CLASS	216		Body	UCP - Upper control panel																																	
CL-CLASS	216		Body	System diagnosis																																	
CL-CLASS	216		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	216		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	216		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	216		Body	RCM - Rear control module																																	
CL-CLASS	216		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
CL-CLASS	216		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	216		Body	Headlamp-R - Headlamp control unit																				V				V									
CL-CLASS	216		Body	Headlamp/Headlamp-L - Headlamp control unit																				V				V									
CL-CLASS	216		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	216		Body	CGW - Central gateway																																	
CL-CLASS	216		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	216		Body	AHE - Trailer recognition																																	
CL-CLASS	216		Body	AB - Airbag																																	
CL-CLASS	216		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	216		Information	VCS - Voice control																																	
CL-CLASS	216		Information	TV - TV tuner																																	
CL-CLASS	216		Information	Tuner - Standard tuner																																	
CL-CLASS	216		Information	SGR - Radar sensors control unit																																	
CL-CLASS	216		Information	MFK - Multifunction camera																																	
CL-CLASS	216		Information	RFK - Backup camera																																	
CL-CLASS	216		Information	PTS - Parktronic system																																	
CL-CLASS	216		Information	NSA - Night View Assist																																	
CL-CLASS	216		Information	NBR-LF - Left front range radar																																	
CL-CLASS	216		Information	NAV - Navigation module																																	
CL-CLASS	216		Information	MIF/UCI - Media interface																																	
CL-CLASS	216		Information	ICI - InCar Internet																																	
CL-CLASS	216		Information	IC - Instrument cluster																																	
CL-CLASS	216		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	216		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	216		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	216		Information	AUDIO/COMAND																																	
CL-CLASS	216		Information	ASSYST PLUS - PLUS Active Service System																																	
CL-CLASS	216		Information	ASSYST Active Service System																																	
CL-CLASS	216		Seat/Door	TLC/GTO - Garage door opener																																	
CL-CLASS	216		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	216		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	216		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	216		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	216		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
CL-CLASS	216		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	216		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	216		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	217		Drive	SCR - Selective catalytic reduction																														V			
CL-CLASS	217		Drive	SG-EM - Power electronics																																	
CL-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	217		Drive	DTR - Distronic																																	
CL-CLASS	217		Drive	ISM - Intelligent servo module																																	
CL-CLASS	217		Drive	ME/CDI/CNG - Engine control unit									V		V		V												V		V	V	V			V
CL-CLASS	217		Drive	ETC - Electronic transmission control																															V		
CL-CLASS	217		Drive	PTCU - Common powertrain controller																																	
CL-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	217		Chassis	ABS/ESP - Electronic stability program																										V							
CL-CLASS	217		Chassis	ES - Electrical power steering										V																							
CL-CLASS	217		Chassis	Suspension																																	
CL-CLASS	217		Chassis	EFB - Electric parking brake																																	
CL-CLASS	217		Information	TPAD - Touchpad																																	
CL-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	217		Information	360' - Camera																																	
CL-CLASS	217		Information	SOUND - Sound system																																	
CL-CLASS	217		Information	RFK - Backup camera																																	
CL-CLASS	217		Information	SGR - Radar sensors control unit																					V												
CL-CLASS	217		Information	PTS - Parktronic system																																	
CL-CLASS	217		Information	NSA - Night View Assist																																	
CL-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CL-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CL-CLASS	217		Information	NBR-RF - Right front range radar																																	
CL-CLASS	217		Information	NBR-LF - Left front range radar																																	
CL-CLASS	217		Information	MFK - Multifunction camera																																	
CL-CLASS	217		Information	Head-up display																																	
CL-CLASS	217		Information	AUDIO/COMAND																																	
CL-CLASS	217		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	217		Information	KAB - Camera cover																																	
CL-CLASS	217		Information	IC - Instrument cluster															V																		
CL-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
CL-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CL-CLASS	217		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	AB - Airbag																																	
CL-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
CL-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	217		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	217		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
CL-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
CL-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	170		Drive	ME/CDI/CNG - Engine control unit																																	
SLK-CLASS	170		Drive	ETC - Electronic transmission control																						V	V										
SLK-CLASS	170		Drive	ESM - Electronic selector module																																	
SLK-CLASS	170		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	170		Chassis	VP - Vacuum pump brake booster																																	
SLK-CLASS	170		Chassis	BAS - Brake assist																																	
SLK-CLASS	170		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	170		Body	AB - Airbag																																	
SLK-CLASS	170		Information	IC - Instrument cluster																V																	
SLK-CLASS	170		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	170		Information	AUDIO/COMAND																																	
SLK-CLASS	170		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
SLK-CLASS	170		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	171		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V																	V		V		V				V
SLK-CLASS	171		Drive	ETC - Electronic transmission control																						V	V										
SLK-CLASS	171		Drive	ESM - Electronic selector module																																	
SLK-CLASS	171		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	171		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	171		Body	WSS - Weight sensing system																																	
SLK-CLASS	171		Body	UCP - Upper control panel																																	
SLK-CLASS	171		Body	System diagnosis																																	
SLK-CLASS	171		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	171		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	171		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLK-CLASS	171		Body	OCP - Overhead control panel																																	
SLK-CLASS	171		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	171		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	171		Body	CGW - Central gateway																																	
SLK-CLASS	171		Body	AB - Airbag																																	
SLK-CLASS	171		Information	TV - TV tuner																																	
SLK-CLASS	171		Information	SOUND - Sound system																																	
SLK-CLASS	171		Information	PTS - Parktronic system																																	
SLK-CLASS	171		Information	MIF/UCI - Media interface																																	
SLK-CLASS	171		Information	IC - Instrument cluster																																	
SLK-CLASS	171		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	171		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	171		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SLK-CLASS	171		Information	AUDIO/COMAND																																	
SLK-CLASS	171		Information	ASSYST PLUS - PLUS Active Service System														V																			
SLK-CLASS	171		Information	ASSYST Active Service System																																	
SLK-CLASS	171		Information	AGW - Audio gateway																																	
SLK-CLASS	171		Seat/Door	RVC/VDS - Convertible roof control																									V								
SLK-CLASS	171		Seat/Door	HS - Seat heater																																	
SLK-CLASS	171		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	171		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	171		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	171		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	171		Air Conditioning	AAC - Automatic air conditioning																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
SLK-CLASS	172		Drive	ME/CDI/CNG - Engine control unit									V		V		V													V		V	V	V			V
SLK-CLASS	172		Drive	ETC - Electronic transmission control																						V	V										
SLK-CLASS	172		Drive	ESM - Electronic selector module																																	
SLK-CLASS	172		Drive	DTR - Distronic																																	
SLK-CLASS	172		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLK-CLASS	172		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	172		Chassis	Suspension																			V														
SLK-CLASS	172		Chassis	ES - Electrical power steering																																	
SLK-CLASS	172		Chassis	EFB - Electric parking brake																																	
SLK-CLASS	172		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	172		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	172		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	172		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLK-CLASS	172		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	172		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLK-CLASS	172		Body	Headlamp/Headlamp-L - Headlamp control unit																				V													
SLK-CLASS	172		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	172		Body	CGW - Central gateway																																	
SLK-CLASS	172		Body	AB - Airbag																																	
SLK-CLASS	172		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SLK-CLASS	172		Information	ZAN - Audio/COMAND display																																	
SLK-CLASS	172		Information	TV - TV tuner																																	
SLK-CLASS	172		Information	SOUND - Sound system																																	
SLK-CLASS	172		Information	SGR - Radar sensors control unit																																	
SLK-CLASS	172		Information	MFK - Multifunction camera																																	
SLK-CLASS	172		Information	PTS - Parktronic system																																	
SLK-CLASS	172		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLK-CLASS	172		Information	NBR-RF - Right front range radar																																	
SLK-CLASS	172		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLK-CLASS	172		Information	NBR-LF - Left front range radar																																	
SLK-CLASS	172		Information	NAV - Navigation module																																	
SLK-CLASS	172		Information	MIF/UCI - Media interface																																	
SLK-CLASS	172		Information	IC - Instrument cluster														V	V																		
SLK-CLASS	172		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
SLK-CLASS	172		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	172		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLK-CLASS	172		Information	AUDIO/COMAND																																	
SLK-CLASS	172		Seat/Door	RVC/VDS - Convertible roof control																																	
SLK-CLASS	172		Seat/Door	PSD/MSC - Sliding roof control																																	
SLK-CLASS	172		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	172		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	172		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	172		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	172		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	129		Drive	ME/CDI/CNG - Engine control unit																																	
SL-CLASS	129		Drive	ETC - Electronic transmission control																																	
SL-CLASS	129		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	129		Chassis	BAS - Brake assist																																	
SL-CLASS	129		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	129		Body	AB - Airbag																																	
SL-CLASS	129		Information	NAV - Navigation module																																	
SL-CLASS	129		Information	IC - Instrument cluster																V																	
SL-CLASS	129		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	129		Information	AUDIO/COMAND																																	
SL-CLASS	129		Information	APS - Auto pilot system																																	
SL-CLASS	129		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	129		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	230		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V																	V		V		V			V
SL-CLASS	230		Drive	ETC - Electronic transmission control																					V	V											
SL-CLASS	230		Drive	ESM - Electronic selector module																																	
SL-CLASS	230		Drive	DTR - Distronic																																	
SL-CLASS	230		Drive	AMG DRIVE UNIT																																	
SL-CLASS	230		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	230		Chassis	Suspension																																	
SL-CLASS	230		Chassis	SBC - Sensotronic Brake Control																																	
SL-CLASS	230		Chassis	PSE - Pneumatic system equipment																																	
SL-CLASS	230		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	230		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	230		Body	WSS - Weight sensing system																																	
SL-CLASS	230		Body	System diagnosis																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
SL-CLASS	230		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	230		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	230		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SL-CLASS	230		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	230		Body	OCP - Overhead control panel																																	
SL-CLASS	230		Body	LCP/HBF - Lower/Rear control panel																																	
SL-CLASS	230		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	230		Body	HSW/LRH - Steering wheel heater																																	
SL-CLASS	230		Body	Headlamp-R - Headlamp control unit																								V									
SL-CLASS	230		Body	Headlamp/Headlamp-L - Headlamp control unit																								V									
SL-CLASS	230		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	230		Body	CGW - Central gateway																																	
SL-CLASS	230		Body	BNS/BMS - Battery sensor																																	
SL-CLASS	230		Body	AB - Airbag																																	
SL-CLASS	230		Information	TV - TV tuner																																	
SL-CLASS	230		Information	SOUND - Sound system																																	
SL-CLASS	230		Information	PTS - Parktronic system																																	
SL-CLASS	230		Information	MIF/UCI - Media interface																																	
SL-CLASS	230		Information	IC - Instrument cluster																																	
SL-CLASS	230		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	230		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	230		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SL-CLASS	230		Information	AUDIO/COMAND																																	
SL-CLASS	230		Information	AGW - Audio gateway																																	
SL-CLASS	230		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	230		Seat/Door	OSB-FR - Multicontour backrest front right																																	
SL-CLASS	230		Seat/Door	OSB-FL - Multicontour backrest front left																																	
SL-CLASS	230		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	230		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	230		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	230		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	230		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	230		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	231		Drive	ME/CDI/CNG - Engine control unit									V		V		V												V		V	V	V			V
SL-CLASS	231		Drive	ETC - Electronic transmission control																														V			
SL-CLASS	231		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
SL-CLASS	231		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SL-CLASS	231		Drive	DTR - Distronic																																	
SL-CLASS	231		Drive	DSI - Direct select interface																																	
SL-CLASS	231		Drive	AMG DRIVE UNIT																																	
SL-CLASS	231		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	231		Chassis	Suspension																			V														
SL-CLASS	231		Chassis	ES - Electrical power steering										V								V															
SL-CLASS	231		Chassis	EFB - Electric parking brake																																	
SL-CLASS	231		Chassis	FWGW - Chassis gateway																																	
SL-CLASS	231		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	231		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	231		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	231		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	231		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	231		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	231		Body	Headlamp/Headlamp-L - Headlamp control unit																				V													
SL-CLASS	231		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	231		Body	CGW - Central gateway																																	
SL-CLASS	231		Body	AB - Airbag																																	
SL-CLASS	231		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SL-CLASS	231		Information	ZAN - Audio/COMAND display																																	
SL-CLASS	231		Information	TV - TV tuner																																	
SL-CLASS	231		Information	SOUND - Sound system																																	
SL-CLASS	231		Information	SGR - Radar sensors control unit																																	
SL-CLASS	231		Information	RFK - Backup camera																																	
SL-CLASS	231		Information	MFK - Multifunction camera																																	
SL-CLASS	231		Information	PTS - Parktronic system																																	
SL-CLASS	231		Information	NSA - Night View Assist																																	
SL-CLASS	231		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SL-CLASS	231		Information	NBR-RF - Right front range radar																																	
SL-CLASS	231		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SL-CLASS	231		Information	NBR-LF - Left front range radar																																	
SL-CLASS	231		Information	MIF/UCI - Media interface																																	
SL-CLASS	231		Information	IC - Instrument cluster														V	V																		

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
SL-CLASS	231		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	231		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	231		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SL-CLASS	231		Information	AUDIO/COMAND																																	
SL-CLASS	231		Information	AMG Performance Media																																	
SL-CLASS	231		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	231		Seat/Door	PSD/MSC - Sliding roof control																																	
SL-CLASS	231		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	231		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	231		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
SL-CLASS	231		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	231		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	231		Air Conditioning	AAC - Automatic air conditioning																																	
SLS-CLASS	197		Drive	PTCU - Common powertrain controller																																	
SLS-CLASS	197		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V																	V		V		V			V
SLS-CLASS	197		Drive	ETC - Electronic transmission control																															V		
SLS-CLASS	197		Drive	ISM - Intelligent servo module																																	
SLS-CLASS	197		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLS-CLASS	197		Drive	DSI - Direct select interface																																	
SLS-CLASS	197		Drive	AMG DRIVE UNIT																																	
SLS-CLASS	197		Chassis	ABS/ESP - Electronic stability program																																	
SLS-CLASS	197		Chassis	Suspension																			V														
SLS-CLASS	197		Chassis	ES - Electrical power steering																																	
SLS-CLASS	197		Chassis	EFB - Electric parking brake																																	
SLS-CLASS	197		Chassis	TPM - Tire pressure monitor																																	
SLS-CLASS	197		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	CSHV - Crash sensor/high-voltage battery																																	
SLS-CLASS	197		Body	BNS/BMS - Battery sensor									V		V		V													V		V	V	V	V		V
SLS-CLASS	197		Body	WSS - Weight sensing system																																	
SLS-CLASS	197		Body	SCM [MRM] - Steering column module																																	
SLS-CLASS	197		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLS-CLASS	197		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLS-CLASS	197		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
SLS-CLASS	197		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLS-CLASS	197		Body	EZS/EIS - Electronic ignition lock																																	
SLS-CLASS	197		Body	CGW - Central gateway																																	
SLS-CLASS	197		Body	AB - Airbag																																	
SLS-CLASS	197		Information	MFK - Multifunction camera																																	
SLS-CLASS	197		Information	SGR - Radar sensors control unit																																	
SLS-CLASS	197		Information	ZAN - Audio/COMAND display																																	
SLS-CLASS	197		Information	SOUND - Sound system																																	
SLS-CLASS	197		Information	PTS - Parktronic system																																	
SLS-CLASS	197		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLS-CLASS	197		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLS-CLASS	197		Information	MIF/UCI - Media interface																																	
SLS-CLASS	197		Information	IC - Instrument cluster														V	V																		
SLS-CLASS	197		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLS-CLASS	197		Information	DAB/SDAR - Digital/Satellite radio																																	
SLS-CLASS	197		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLS-CLASS	197		Information	AUDIO/COMAND																																	
SLS-CLASS	197		Information	AMG Performance Media																																	
SLS-CLASS	197		Seat/Door	RVC/VDS - Convertible roof control																																	
SLS-CLASS	197		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLS-CLASS	197		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLS-CLASS	197		Seat/Door	DCM-FR - Door control module front right																																	
SLS-CLASS	197		Seat/Door	DCM-FL - Door control module front left																																	
SLS-CLASS	197		Air Conditioning	AAC - Automatic air conditioning																																	
AMG GT	190		Drive	DTR - Distronic																																	
AMG GT	190		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
AMG GT	190		Drive	DSI - Direct select interface																																	
AMG GT	190		Drive	AMG DRIVE UNIT																																	
AMG GT	190		Drive	PTCU - Common powertrain controller																																	
AMG GT	190		Drive	ME/CDI/CNG - Engine control unit									V		V		V												V		V	V	V			V
AMG GT	190		Drive	ETC - Electronic transmission control																														V		
AMG GT	190		Chassis	TPM - Tire pressure monitor																																	
AMG GT	190		Chassis	Suspension																			V														
AMG GT	190		Chassis	ABS/ESP - Electronic stability program																																	
AMG GT	190		Chassis	EFB - Electric parking brake																																	
AMG GT	190		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
AMG GT	190		Information	DAB/SDAR - Digital/Satellite radio																																	
AMG GT	190		Information	SOUND - Sound system																																	
AMG GT	190		Information	RFK - Backup camera																																	
AMG GT	190		Information	PTS - Parktronic system																																	
AMG GT	190		Information	MFK - Multifunction camera																																	
AMG GT	190		Information	IC - Instrument cluster															V																		
AMG GT	190		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
AMG GT	190		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
AMG GT	190		Information	AUDIO/COMAND																																	
AMG GT	190		Information	ZAN - Audio/COMAND display																																	
AMG GT	190		Information	COU [ZBE] - Audio/COMAND operating unit																																	
AMG GT	190		Information	DTA - Mbrace or TELEAID/GPS Box																																	
AMG GT	190		Information	AMG Performance Media																																	
AMG GT	190		Body	SCM [MRM] - Steering column module																																	
AMG GT	190		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
AMG GT	190		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
AMG GT	190		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
AMG GT	190		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
AMG GT	190		Body	AB - Airbag																																	
AMG GT	190		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
AMG GT	190		Body	Headlamp-R - Headlamp control unit																				V													
AMG GT	190		Body	Headlamp/Headlamp-L - Headlamp control unit																				V													
AMG GT	190		Body	SG-AWF - Collision prevention assist																																	
AMG GT	190		Body	EZS/EIS - Electronic ignition lock																																	
AMG GT	190		Body	CGW - Central gateway																																	
AMG GT	190		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
AMG GT	190		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
AMG GT	190		Seat/Door	DCM-FR - Door control module front right																																	
AMG GT	190		Seat/Door	DCM-FL - Door control module front left																																	
AMG GT	190		Air Conditioning	AAC - Automatic air conditioning																																	
SLR-CLASS	199		Drive	ME/CDI/CNG - Engine control unit																																	
SLR-CLASS	199		Drive	ETC - Electronic transmission control																						V	V										
SLR-CLASS	199		Drive	ESM - Electronic selector module																																	
SLR-CLASS	199		Chassis	ABS/ESP - Electronic stability program																																	
SLR-CLASS	199		Chassis	SBC - Sensotronic Brake Control																																	
SLR-CLASS	199		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
SLR-CLASS	199		Body	WSS - Weight sensing system																																	
SLR-CLASS	199		Body	SCM [MRM] - Steering column module																																	
SLR-CLASS	199		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLR-CLASS	199		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SLR-CLASS	199		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLR-CLASS	199		Body	OCP - Overhead control panel																																	
SLR-CLASS	199		Body	LCP/HBF - Lower/Rear control panel																																	
SLR-CLASS	199		Body	Headlamp-R - Headlamp control unit																																	
SLR-CLASS	199		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLR-CLASS	199		Body	EZS/EIS - Electronic ignition lock																																	
SLR-CLASS	199		Body	CGW - Central gateway																																	
SLR-CLASS	199		Body	BNS/BMS - Battery sensor																																	
SLR-CLASS	199		Body	AB - Airbag																																	
SLR-CLASS	199		Information	IC - Instrument cluster																																	
SLR-CLASS	199		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLR-CLASS	199		Information	AUDIO/COMAND																																	
SLR-CLASS	199		Seat/Door	DCM-FR - Door control module front right																																	
SLR-CLASS	199		Seat/Door	DCM-FL - Door control module front left																																	
SLR-CLASS	199		Air Conditioning	AAC - Automatic air conditioning																																	
MAYBACH	240		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V																	V		V		V			V
MAYBACH	240		Drive	ETC - Electronic transmission control																					V	V											
MAYBACH	240		Drive	ESM - Electronic selector module																																	
MAYBACH	240		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
MAYBACH	240		Drive	DTR - Distronic	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
MAYBACH	240		Chassis	ABS/ESP - Electronic stability program																																	
MAYBACH	240		Chassis	Suspension																																	
MAYBACH	240		Chassis	SBC - Sensotronic Brake Control																																	
MAYBACH	240		Chassis	TPM - Tire pressure monitor																																	
MAYBACH	240		Body	WSS - Weight sensing system																																	
MAYBACH	240		Body	System diagnosis																																	
MAYBACH	240		Body	SCM [MRM] - Steering column module																																	
MAYBACH	240		Body	HSW/LRH - Steering wheel heater																																	
MAYBACH	240		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
MAYBACH	240		Body	AB - Airbag																																	
MAYBACH	240		Information	TV - TV tuner																																	
MAYBACH	240		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
MAYBACH	240		Information	DTA - Mbrace or TELEAID/GPS Box																																	
MAYBACH	240		Information	AGW - Audio gateway																																	
MAYBACH	240		Seat/Door	REDC/RWT - Rear end door control module																																	
MAYBACH	240		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All_Model(BETA)	16P Connector		Drive	SG-EM - Power electronics																																	
All_Model(BETA)	16P Connector		Drive	HFPM - Haptic accelerator pedal module																																	
All_Model(BETA)	16P Connector		Drive	ME/CDI/CNG - Engine control unit	V	V	V	V				V	V		V		V													V		V	V	V			V
All_Model(BETA)	16P Connector		Drive	ETC - Electronic transmission control																					V	V									V		
All_Model(BETA)	16P Connector		Drive	ESM - Electronic selector module																																	
All_Model(BETA)	16P Connector		Drive	VG - Transfer case																																	
All_Model(BETA)	16P Connector		Drive	VECU - Power monitoring control unit																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-B - Electric motor control unit B																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-A - Electric motor control unit A																																	
All_Model(BETA)	16P Connector		Drive	SCR - Selective catalytic reduction																														V			
All_Model(BETA)	16P Connector		Drive	PTCU - Common powertrain controller																																	
All_Model(BETA)	16P Connector		Drive	Natural gas control unit																																	
All_Model(BETA)	16P Connector		Drive	ISM - Intelligent servo module																																	
All_Model(BETA)	16P Connector		Drive	Hydrogen tank control unit																																	
All_Model(BETA)	16P Connector		Drive	HSG - Hybrid control unit																										V							
All_Model(BETA)	16P Connector		Drive	High-temperature coolant pump control unit																																	
All_Model(BETA)	16P Connector		Drive	Fuel cell control unit																																	
All_Model(BETA)	16P Connector		Drive	FSCU-R - Control unit fuel pump																																	
All_Model(BETA)	16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
All_Model(BETA)	16P Connector		Drive	EMPI - Electronic Motor Pump Inverter																																	
All_Model(BETA)	16P Connector		Drive	Electric drive control unit																																	
All_Model(BETA)	16P Connector		Drive	DTR - Distronic																					V												
All_Model(BETA)	16P Connector		Drive	DSI - Direct select interface																																	
All_Model(BETA)	16P Connector		Drive	Compressed Natural Gas Control Module																																	
All_Model(BETA)	16P Connector		Drive	CC - Cruise control																																	
All_Model(BETA)	16P Connector		Drive	BSA - Belt-driven starter/alternator																																	
All_Model(BETA)	16P Connector		Drive	AMG DRIVE UNIT																																	
All_Model(BETA)	16P Connector		Drive	ACS - Automatic clutch system																																	
All_Model(BETA)	16P Connector		Chassis	ABS/ESP - Electronic stability program																																	
All_Model(BETA)	16P Connector		Chassis	Suspension																			V														
All_Model(BETA)	16P Connector		Chassis	SBC - Sensotronic Brake Control																																	
All_Model(BETA)	16P Connector		Chassis	PSE - Pneumatic system equipment																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
All_Model(BETA)	16P Connector		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
All_Model(BETA)	16P Connector		Chassis	HAQ - Interwheel differential lock at rear axle																																	
All_Model(BETA)	16P Connector		Chassis	FWGW - Chassis gateway																																	
All_Model(BETA)	16P Connector		Chassis	ES - Electrical power steering										V								V															
All_Model(BETA)	16P Connector		Chassis	EFB - Electric parking brake																																	
All_Model(BETA)	16P Connector		Chassis	BAS - Brake assist																																	
All_Model(BETA)	16P Connector		Chassis	VP - Vacuum pump brake booster																																	
All_Model(BETA)	16P Connector		Chassis	TPM - Tire pressure monitor																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
All_Model(BETA)	16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
All_Model(BETA)	16P Connector		Body	CSHV - Crash sensor/high-voltage battery																																	
All_Model(BETA)	16P Connector		Body	WSS - Weight sensing system																																	
All_Model(BETA)	16P Connector		Body	UCP - Upper control panel																																	
All_Model(BETA)	16P Connector		Body	System diagnosis																																	
All_Model(BETA)	16P Connector		Body	SG-DDW - DC/DC converter control unit																																	
All_Model(BETA)	16P Connector		Body	SG-AWF - Collision prevention assist																																	
All_Model(BETA)	16P Connector		Body	SCM [MRM] - Steering column module																																	
All_Model(BETA)	16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
All_Model(BETA)	16P Connector		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
All_Model(BETA)	16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
All_Model(BETA)	16P Connector		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
All_Model(BETA)	16P Connector		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
All_Model(BETA)	16P Connector		Body	RCM - Rear control module																																	
All_Model(BETA)	16P Connector		Body	OCP - Overhead control panel																																	
All_Model(BETA)	16P Connector		Body	Multifunction control unit																																	
All_Model(BETA)	16P Connector		Body	LCP/HBF - Lower/Rear control panel																																	
All_Model(BETA)	16P Connector		Body	LAE [LAA] - Loading floor automatically extendable																																	
All_Model(BETA)	16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
All_Model(BETA)	16P Connector		Body	HSW/LRH - Steering wheel heater																																	
All_Model(BETA)	16P Connector		Body	Headlamp-R - Headlamp control unit																				V				V									
All_Model(BETA)	16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																				V				V									
All_Model(BETA)	16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
All_Model(BETA)	16P Connector		Body	CGW - Central gateway																																	
All_Model(BETA)	16P Connector		Body	BNS/BMS - Battery sensor																																	
All_Model(BETA)	16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
All_Model(BETA)	16P Connector		Body	AHE - Trailer recognition																																	
All_Model(BETA)	16P Connector		Body	AB - Airbag																																	
All_Model(BETA)	16P Connector		Body	AAM - All activity module																																	
All_Model(BETA)	16P Connector		Information	TPAD - Touchpad																																	
All_Model(BETA)	16P Connector		Information	Head-up display																																	
All_Model(BETA)	16P Connector		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
All_Model(BETA)	16P Connector		Information	KAB - Camera cover																																	
All_Model(BETA)	16P Connector		Information	ZAN - Audio/COMAND display																																	
All_Model(BETA)	16P Connector		Information	VCS - Voice control																																	
All_Model(BETA)	16P Connector		Information	TV - TV tuner																																	
All_Model(BETA)	16P Connector		Information	Tuner - Standard tuner																																	
All_Model(BETA)	16P Connector		Information	Sound generator for exhaust system																																	
All_Model(BETA)	16P Connector		Information	SOUND - Sound system																																	
All_Model(BETA)	16P Connector		Information	SGR - Radar sensors control unit																																	
All_Model(BETA)	16P Connector		Information	360' - Camera																																	
All_Model(BETA)	16P Connector		Information	MFK - Multifunction camera																																	
All_Model(BETA)	16P Connector		Information	RFK - Backup camera																	V																
All_Model(BETA)	16P Connector		Information	PTS - Parktronic system																																	
All_Model(BETA)	16P Connector		Information	NSA - Night View Assist																																	
All_Model(BETA)	16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-RF - Right front range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LF - Left front range radar																																	
All_Model(BETA)	16P Connector		Information	NAV - Navigation module																																	
All_Model(BETA)	16P Connector		Information	MIF/UCI - Media interface																																	
All_Model(BETA)	16P Connector		Information	ICI - InCar Internet																																	
All_Model(BETA)	16P Connector		Information	IC - Instrument cluster														V	V	V																	
All_Model(BETA)	16P Connector		Information	DVD player																																	
All_Model(BETA)	16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
All_Model(BETA)	16P Connector		Information	D-FOR - Display in right rear passenger																																	
All_Model(BETA)	16P Connector		Information	D-FOL - Display in left rear passenger																																	
All_Model(BETA)	16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
All_Model(BETA)	16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
All_Model(BETA)	16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
All_Model(BETA)	16P Connector		Information	CM - Compass module																																	
All_Model(BETA)	16P Connector		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement
All Model(BETA)	16P Connector		Information	AUDIO/COMAND																																	
All Model(BETA)	16P Connector		Information	ASSYST PLUS - PLUS Active Service System														V																			
All Model(BETA)	16P Connector		Information	ASSYST Active Service System																																	
All Model(BETA)	16P Connector		Information	APS - Auto pilot system																																	
All Model(BETA)	16P Connector		Information	AMG Performance Media																																	
All Model(BETA)	16P Connector		Information	AGW - Audio gateway																																	
All Model(BETA)	16P Connector		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-MR - Right center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-ML - Left center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TLC/GTO - Garage door opener																																	
All Model(BETA)	16P Connector		Seat/Door	RVC/VDS - Convertible roof control																																	
All Model(BETA)	16P Connector		Seat/Door	REDC/RWT - Rear end door control module																																	
All Model(BETA)	16P Connector		Seat/Door	PSD/MSC - Sliding roof control																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-R - Multicontour backrest rear																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FR - Multicontour backrest front right																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FL - Multicontour backrest front left																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	HS - Seat heater																																	
All Model(BETA)	16P Connector		Seat/Door	HKS - Tailgate control																																	
All Model(BETA)	16P Connector		Seat/Door	ESA-R - Electric seat adjustment rear																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
All Model(BETA)	16P Connector		Seat/Door	ERA - Electric fold down backrest system																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-RR - Door control module rear right																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-RL - Door control module rear left																								V									
All Model(BETA)	16P Connector		Seat/Door	DCM-FR - Door control module front right																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-FL - Door control module front left																																	
All Model(BETA)	16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All Model(BETA)	16P Connector		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
All Model(BETA)	16P Connector		Air Conditioning	HBF - Rear control panel																																	
All Model(BETA)	16P Connector		Air Conditioning	HB - Heater booster																																	
All Model(BETA)	16P Connector		Air Conditioning	EKMK - Electric refrigerant compressor																																	
All Model(BETA)	16P Connector		Air Conditioning	AAC - Automatic air conditioning																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
A-CLASS	68		Drive	ME/CDI/CNG - Engine control unit																																	
A-CLASS	68		Drive	ETC - Electronic transmission control								V																									
A-CLASS	68		Drive	ESM - Electronic selector module																																	
A-CLASS	68		Drive	ACS - Automatic clutch system																																	
A-CLASS	68		Chassis	ABS/ESP - Electronic stability program																			V										V				
A-CLASS	168		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Body	LCP/HBF - Lower/Rear control panel																																	
A-CLASS	168		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	168		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	168		Body	AB - Airbag																																	
A-CLASS	168		Information	PTS - Parktronic system																																	
A-CLASS	168		Information	IC - Instrument cluster																																	
A-CLASS	168		Information	AUDIO/COMAND																																	
A-CLASS	168		Information	APS - Auto pilot system																																	
A-CLASS	168		Seat/Door	DCM-RR - Door control module rear right																																	
A-CLASS	168		Seat/Door	DCM-RL - Door control module rear left																																	
A-CLASS	168		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	168		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	168		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	168		Air Conditioning	HB - Heater booster																																	
A-CLASS	168		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	169		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V				V			
A-CLASS	169		Drive	ETC - Electronic transmission control								V																									V
A-CLASS	169		Drive	ESM - Electronic selector module																																	
A-CLASS	169		Drive	BSA - Belt-driven starter/alternator																																	
A-CLASS	169		Chassis	ABS/ESP - Electronic stability program																													V				
A-CLASS	169		Chassis	ES - Electrical power steering																																	
A-CLASS	169		Body	SCM [MRM] - Steering column module																																	
A-CLASS	169		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
A-CLASS	169		Body	OCP - Overhead control panel																																	
A-CLASS	169		Body	Multifunction control unit																																	
A-CLASS	169		Body	Headlamp-R - Headlamp control unit																																	
A-CLASS	169		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
A-CLASS	169		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	169		Body	CGW - Central gateway																																	
A-CLASS	169		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
A-CLASS	169		Body	AHE - Trailer recognition																																	
A-CLASS	169		Body	AB - Airbag																																	
A-CLASS	169		Information	SOUND - Sound system																																	
A-CLASS	169		Information	PTS - Parktronic system																																	
A-CLASS	169		Information	MIF/UCI - Media interface																																	
A-CLASS	169		Information	IC - Instrument cluster																																	
A-CLASS	169		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	169		Information	CTEL/TEL - Cellular/Mobile telephone																																	
A-CLASS	169		Information	AUDIO/COMAND																																	
A-CLASS	169		Information	ASSYST PLUS - PLUS Active Service System																																	
A-CLASS	169		Information	ASSYST Active Service System																																	
A-CLASS	169		Information	AGW - Audio gateway																																	
A-CLASS	169		Seat/Door	DCM-RR - Door control module rear right																																	
A-CLASS	169		Seat/Door	DCM-RL - Door control module rear left																																	
A-CLASS	169		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	169		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	169		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	176		Drive	VG - Transfer case																																	
A-CLASS	176		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V					V			
A-CLASS	176		Drive	ETC - Electronic transmission control																				V													
A-CLASS	176		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
A-CLASS	176		Drive	DTR - Distronic																																	
A-CLASS	176		Drive	DSI - Direct select interface																																	
A-CLASS	176		Drive	PTCU - Common powertrain controller																																	
A-CLASS	176		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	176		Chassis	ES - Electrical power steering																						V											
A-CLASS	176		Chassis	EFB - Electric parking brake																												V					
A-CLASS	176		Chassis	TPM - Tire pressure monitor																																	
A-CLASS	176		Body	SG-AWF - Collision prevention assist																																	
A-CLASS	176		Body	SCM [MRM] - Steering column module																																	
A-CLASS	176		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
A-CLASS	176		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	Multifunction control unit																																	
A-CLASS	176		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	176		Body	Headlamp/Headlamp-L - Headlamp control unit												V												V	V								

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
A-CLASS	176		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	176		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	176		Body	AHE - Trailer recognition																																	
A-CLASS	176		Body	AB - Airbag																																	
A-CLASS	176		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
A-CLASS	176		Information	ZAN - Audio/COMAND display																																	
A-CLASS	176		Information	TV - TV tuner																																	
A-CLASS	176		Information	SOUND - Sound system																																	
A-CLASS	176		Information	RFK - Backup camera																																	
A-CLASS	176		Information	MFK - Multifunction camera																																	
A-CLASS	176		Information	PTS - Parktronic system																																	
A-CLASS	176		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
A-CLASS	176		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
A-CLASS	176		Information	NAV - Navigation module																																	
A-CLASS	176		Information	MIF/UCI - Media interface																																	
A-CLASS	176		Information	IC - Instrument cluster							V																										
A-CLASS	176		Information	DTA - Mbrace or TELEAID/GPS Box																																	
A-CLASS	176		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	176		Information	COU [ZBE] - Audio/COMAND operating unit																																	
A-CLASS	176		Information	AUDIO/COMAND																																	
A-CLASS	176		Seat/Door	PSD/MSC - Sliding roof control																																	
A-CLASS	176		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
A-CLASS	176		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
A-CLASS	176		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	176		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	176		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	176		Air Conditioning	AAC - Automatic air conditioning																																	
B-CLASS	245		Drive	ME/CDI/CNG - Engine control unit								V									V	V				V											
B-CLASS	245		Drive	ETC - Electronic transmission control								V																									V
B-CLASS	245		Drive	ESM - Electronic selector module																																	
B-CLASS	245		Drive	Hydrogen tank control unit																																	
B-CLASS	245		Drive	High-temperature coolant pump control unit																																	
B-CLASS	245		Drive	Fuel cell control unit																																	
B-CLASS	245		Drive	Electric drive control unit																																	
B-CLASS	245		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	245		Drive	BSA - Belt-driven starter/alternator																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
B-CLASS	245		Drive	VECU - Power monitoring control unit																																	
B-CLASS	245		Chassis	ABS/ESP - Electronic stability program																													V				
B-CLASS	245		Chassis	ES - Electrical power steering																																	
B-CLASS	245		Chassis	VP - Vacuum pump brake booster																																	
B-CLASS	245		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	245		Body	WSS - Weight sensing system																																	
B-CLASS	245		Body	SG-DDW - DC/DC converter control unit																																	
B-CLASS	245		Body	SCM [MRM] - Steering column module																																	
B-CLASS	245		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
B-CLASS	245		Body	OCP - Overhead control panel																																	
B-CLASS	245		Body	Multifunction control unit																																	
B-CLASS	245		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	245		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	245		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	245		Body	CGW - Central gateway																																	
B-CLASS	245		Body	BNS/BMS - Battery sensor																																	
B-CLASS	245		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	245		Body	AHE - Trailer recognition																																	
B-CLASS	245		Body	AB - Airbag																																	
B-CLASS	245		Information	SOUND - Sound system																																	
B-CLASS	245		Information	PTS - Parktronic system																																	
B-CLASS	245		Information	NAV - Navigation module																																	
B-CLASS	245		Information	MIF/UCI - Media interface																																	
B-CLASS	245		Information	IC - Instrument cluster																																	
B-CLASS	245		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	245		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	245		Information	CTEL/TEL - Cellular/Mobile telephone																																	
B-CLASS	245		Information	CM - Compass module																																	
B-CLASS	245		Information	AUDIO/COMAND																																	
B-CLASS	245		Information	ASSYST PLUS - PLUS Active Service System																																	
B-CLASS	245		Information	ASSYST Active Service System																																	
B-CLASS	245		Information	AGW - Audio gateway																																	
B-CLASS	245		Seat/Door	DCM-RR - Door control module rear right																																	
B-CLASS	245		Seat/Door	DCM-RL - Door control module rear left																																	
B-CLASS	245		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	245		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
B-CLASS	245		Air Conditioning	EKMK - Electric refrigerant compressor																																	
B-CLASS	245		Air Conditioning	AAC - Automatic air conditioning																																	
B-CLASS	246		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	246		Drive	VG - Transfer case																																	
B-CLASS	246		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V				V			
B-CLASS	246		Drive	ETC - Electronic transmission control																				V													
B-CLASS	246		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
B-CLASS	246		Drive	DTR - Distronic																																	
B-CLASS	246		Drive	PTCU - Common powertrain controller																																	
B-CLASS	246		Chassis	ABS/ESP - Electronic stability program																																	
B-CLASS	246		Chassis	ES - Electrical power steering																						V											
B-CLASS	246		Chassis	EFB - Electric parking brake																												V					
B-CLASS	246		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	246		Body	BNS/BMS - Battery sensor																																	
B-CLASS	246		Body	SG-AWF - Collision prevention assist																																	
B-CLASS	246		Body	SCM [MRM] - Steering column module																																	
B-CLASS	246		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
B-CLASS	246		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	Multifunction control unit																																	
B-CLASS	246		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
B-CLASS	246		Body	Headlamp-R - Headlamp control unit													V																				
B-CLASS	246		Body	Headlamp/Headlamp-L - Headlamp control unit												V											V	V									
B-CLASS	246		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	246		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	246		Body	AHE - Trailer recognition																																	
B-CLASS	246		Body	AB - Airbag																																	
B-CLASS	246		Information	Sound generator for exhaust system																																	
B-CLASS	246		Information	Head-up display																																	
B-CLASS	246		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
B-CLASS	246		Information	ZAN - Audio/COMAND display																																	
B-CLASS	246		Information	TV - TV tuner																																	
B-CLASS	246		Information	SOUND - Sound system																																	
B-CLASS	246		Information	RFK - Backup camera																																	
B-CLASS	246		Information	MFK - Multifunction camera																																	
B-CLASS	246		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
B-CLASS	246		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
B-CLASS	246		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
B-CLASS	246		Information	NAV - Navigation module																																	
B-CLASS	246		Information	MIF/UCI - Media interface																																	
B-CLASS	246		Information	IC - Instrument cluster							V																										
B-CLASS	246		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	246		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	246		Information	COU [ZBE] - Audio/COMAND operating unit																																	
B-CLASS	246		Information	AUDIO/COMAND																																	
B-CLASS	246		Seat/Door	PSD/MSC - Sliding roof control																																	
B-CLASS	246		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
B-CLASS	246		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
B-CLASS	246		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	246		Seat/Door	DCM-FL - Door control module front left																																	
B-CLASS	246		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
B-CLASS	246		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	202		Drive	ME/CDI/CNG - Engine control unit																	V	V															
C-CLASS	202		Drive	ETC - Electronic transmission control								V																									V
C-CLASS	202		Drive	ESM - Electronic selector module																																	
C-CLASS	202		Chassis	PSE - Pneumatic system equipment																																	
C-CLASS	202		Chassis	ABS/ESP - Electronic stability program																			V									V					
C-CLASS	202		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	202		Chassis	BAS - Brake assist																																	
C-CLASS	202		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	202		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	202		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	202		Body	OCP - Overhead control panel																																	
C-CLASS	202		Body	AB - Airbag																																	
C-CLASS	202		Information	PTS - Parktronic system																																	
C-CLASS	202		Information	NAV - Navigation module																																	
C-CLASS	202		Information	IC - Instrument cluster																																	
C-CLASS	202		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	202		Information	AUDIO/COMAND																																	
C-CLASS	202		Information	APS - Auto pilot system																																	
C-CLASS	202		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	202		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
C-CLASS	202		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	202		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	202		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	202		Air Conditioning	HB - Heater booster																																	
C-CLASS	202		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	203		Drive	ME/CDI/CNG - Engine control unit								V									V	V					V											
C-CLASS	203		Drive	ETC - Electronic transmission control								V																									V
C-CLASS	203		Drive	ESM - Electronic selector module																																	
C-CLASS	203		Drive	DTR - Distronic																																	
C-CLASS	203		Chassis	ABS/ESP - Electronic stability program																													V				
C-CLASS	203		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	203		Chassis	BAS - Brake assist																																	
C-CLASS	203		Body	WSS - Weight sensing system																																	
C-CLASS	203		Body	UCP - Upper control panel																																	
C-CLASS	203		Body	System diagnosis																																	
C-CLASS	203		Body	SCM [MRM] - Steering column module																																	
C-CLASS	203		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	203		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	203		Body	OCP - Overhead control panel																																	
C-CLASS	203		Body	Multifunction control unit																																	
C-CLASS	203		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	203		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	203		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	203		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	203		Body	CGW - Central gateway																																	
C-CLASS	203		Body	AHE - Trailer recognition																																	
C-CLASS	203		Body	AB - Airbag																																	
C-CLASS	203		Information	TV - TV tuner																																	
C-CLASS	203		Information	SOUND - Sound system																																	
C-CLASS	203		Information	PTS - Parktronic system																																	
C-CLASS	203		Information	NAV - Navigation module																																	
C-CLASS	203		Information	MIF/UCI - Media interface																																	
C-CLASS	203		Information	IC - Instrument cluster																																	
C-CLASS	203		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	203		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	203		Information	CTEL/TEL - Cellular/Mobile telephone																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
C-CLASS	203		Information	AUDIO/COMAND																																	
C-CLASS	203		Information	AGW - Audio gateway																																	
C-CLASS	203		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	203		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	203		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	203		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	203		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	203		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	203		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	203		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	204		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V					V			
C-CLASS	204		Drive	ETC - Electronic transmission control								V												V														V
C-CLASS	204		Drive	ESM - Electronic selector module																																	
C-CLASS	204		Drive	SCR - Selective catalytic reduction	V																																
C-CLASS	204		Drive	ISM - Intelligent servo module																																	
C-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
C-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	204		Drive	DTR - Distronic																																	
C-CLASS	204		Drive	AMG DRIVE UNIT																																	
C-CLASS	204		Drive	PTCU - Common powertrain controller																																	
C-CLASS	204		Chassis	ABS/ESP - Electronic stability program																													V				
C-CLASS	204		Chassis	Suspension																																	
C-CLASS	204		Chassis	ES - Electrical power steering																						V											
C-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	204		Body	WSS - Weight sensing system																																	
C-CLASS	204		Body	SCM [MRM] - Steering column module																																	
C-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V		V	V																												
C-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	OCP - Overhead control panel																																	
C-CLASS	204		Body	Multifunction control unit																																	
C-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	204		Body	Headlamp-R - Headlamp control unit													V																				
C-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit												V												V	V								
C-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
C-CLASS	204		Body	CGW - Central gateway																																	
C-CLASS	204		Body	AHE - Trailer recognition																																	
C-CLASS	204		Body	AB - Airbag																																	
C-CLASS	204		Information	Head-up display																																	
C-CLASS	204		Information	AVE-H - Rear audio video unit																																	
C-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
C-CLASS	204		Information	ZAN - Audio/COMAND display																																	
C-CLASS	204		Information	TV - TV tuner																																	
C-CLASS	204		Information	Sound generator for exhaust system																																	
C-CLASS	204		Information	SOUND - Sound system																																	
C-CLASS	204		Information	SGR - Radar sensors control unit																																	
C-CLASS	204		Information	360' - Camera																																	
C-CLASS	204		Information	MFK - Multifunction camera																																	
C-CLASS	204		Information	RFK - Backup camera																																	
C-CLASS	204		Information	PTS - Parktronic system																																	
C-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	204		Information	NBR-RF - Right front range radar																																	
C-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	204		Information	NBR-LF - Left front range radar																																	
C-CLASS	204		Information	NAV - Navigation module																																	
C-CLASS	204		Information	MIF/UCI - Media interface																																	
C-CLASS	204		Information	ICI - InCar Internet																																	
C-CLASS	204		Information	IC - Instrument cluster							V																										
C-CLASS	204		Information	DVD player																																	
C-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
C-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
C-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
C-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	204		Information	AUDIO/COMAND																																	
C-CLASS	204		Information	AMG Performance Media																																	
C-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	204		Seat/Door	HKS - Tailgate control																																	
C-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
C-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	204		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	205		Drive	SCR - Selective catalytic reduction	V																																
C-CLASS	205		Drive	SG-EM - Power electronics																																	
C-CLASS	205		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	205		Drive	HFPM - Haptic accelerator pedal module																																	
C-CLASS	205		Drive	DTR - Distronic																V																	
C-CLASS	205		Drive	ISM - Intelligent servo module																																	
C-CLASS	205		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V				V			
C-CLASS	205		Drive	ETC - Electronic transmission control																				V													
C-CLASS	205		Drive	PTCU - Common powertrain controller																																	
C-CLASS	205		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	205		Chassis	Suspension																																	
C-CLASS	205		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	205		Chassis	ES - Electrical power steering																																	
C-CLASS	205		Chassis	EFB - Electric parking brake																												V					
C-CLASS	205		Information	TPAD - Touchpad																																	
C-CLASS	205		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	205		Information	360' - Camera																																	
C-CLASS	205		Information	Sound generator for exhaust system																																	
C-CLASS	205		Information	SOUND - Sound system																																	
C-CLASS	205		Information	RFK - Backup camera																																	
C-CLASS	205		Information	SGR - Radar sensors control unit																V																	
C-CLASS	205		Information	PTS - Parktronic system																																	
C-CLASS	205		Information	NBR-RF - Right front range radar																																	
C-CLASS	205		Information	NBR-LF - Left front range radar																																	
C-CLASS	205		Information	MFK - Multifunction camera																																	
C-CLASS	205		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	205		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	205		Information	Head-up display																																	
C-CLASS	205		Information	AUDIO/COMAND																																	
C-CLASS	205		Information	ZAN - Audio/COMAND display																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
C-CLASS	205		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	205		Information	KAB - Camera cover																																	
C-CLASS	205		Information	IC - Instrument cluster																																	
C-CLASS	205		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	205		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
C-CLASS	205		Body	AHE - Trailer recognition																																	
C-CLASS	205		Body	SCM [MRM] - Steering column module																																	
C-CLASS	205		Body	RevETR-RF - Right front reversible emergency tensioning retractor																											V						
C-CLASS	205		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	AB - Airbag																																	
C-CLASS	205		Body	Multifunction control unit																																	
C-CLASS	205		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	205		Body	Headlamp-R - Headlamp control unit														V																			
C-CLASS	205		Body	Headlamp/Headlamp-L - Headlamp control unit			V	V							V																						
C-CLASS	205		Body	SG-AWF - Collision prevention assist																																	
C-CLASS	205		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	205		Body	BNS/BMS - Battery sensor																																	
C-CLASS	205		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	205		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	205		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	205		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	205		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	205		Seat/Door	HKS - Tailgate control																																	
C-CLASS	205		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	205		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	205		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	205		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	205		Seat/Door	RVC/VDS - Convertible roof control																																	
C-CLASS	205		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	124		Drive	PMS/HFM/LH																																	
E-CLASS	124		Drive	ETC - Electronic transmission control																																	
E-CLASS	124		Drive	ISC - Idle speed control																																	
E-CLASS	124		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	124		Body	AB - Airbag																																	
E-CLASS	210		Drive	ME/CDI/CNG - Engine control unit																	V	V															
E-CLASS	210		Drive	ETC - Electronic transmission control								V																									V

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
E-CLASS	210		Drive	ESM - Electronic selector module																																	
E-CLASS	210		Chassis	ABS/ESP - Electronic stability program																			V										V				
E-CLASS	210		Chassis	VP - Vacuum pump brake booster																																	
E-CLASS	210		Chassis	PSE - Pneumatic system equipment																																	
E-CLASS	210		Chassis	BAS - Brake assist																																	
E-CLASS	210		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	210		Body	OCP - Overhead control panel																																	
E-CLASS	210		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	210		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	210		Body	AB - Airbag																																	
E-CLASS	210		Information	TV - TV tuner																																	
E-CLASS	210		Information	PTS - Parktronic system																																	
E-CLASS	210		Information	NAV - Navigation module																																	
E-CLASS	210		Information	IC - Instrument cluster																																	
E-CLASS	210		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	210		Information	AUDIO/COMAND																																	
E-CLASS	210		Information	APS - Auto pilot system																																	
E-CLASS	210		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	210		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	210		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	210		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	210		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	210		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	210		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	210		Air Conditioning	HB - Heater booster																																	
E-CLASS	210		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	211		Drive	ME/CDI/CNG - Engine control unit								V									V	V					V											
E-CLASS	211		Drive	ETC - Electronic transmission control								V																									V
E-CLASS	211		Drive	ESM - Electronic selector module																																	
E-CLASS	211		Drive	Natural gas control unit																																	
E-CLASS	211		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	211		Drive	DTR - Distronic																																	
E-CLASS	211		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	211		Chassis	ABS/ESP - Electronic stability program																													V				
E-CLASS	211		Chassis	Suspension																																	
E-CLASS	211		Chassis	SBC - Sensotronic Brake Control																													V				

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
E-CLASS	211		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	211		Body	WSS - Weight sensing system																																	
E-CLASS	211		Body	UCP - Upper control panel																																	
E-CLASS	211		Body	System diagnosis																																	
E-CLASS	211		Body	SCM [MRM] - Steering column module																																	
E-CLASS	211		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	211		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
E-CLASS	211		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	211		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	OCP - Overhead control panel																																	
E-CLASS	211		Body	Multifunction control unit																																	
E-CLASS	211		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	211		Body	LAE [LAA] - Loading floor automatically extendable																																	
E-CLASS	211		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	211		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	211		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	211		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	211		Body	CGW - Central gateway																																	
E-CLASS	211		Body	BNS/BMS - Battery sensor																																	
E-CLASS	211		Body	AHE - Trailer recognition																																	
E-CLASS	211		Body	AB - Airbag																																	
E-CLASS	211		Information	TV - TV tuner																																	
E-CLASS	211		Information	SOUND - Sound system																																	
E-CLASS	211		Information	PTS - Parktronic system																																	
E-CLASS	211		Information	MIF/UCI - Media interface																																	
E-CLASS	211		Information	IC - Instrument cluster																																	
E-CLASS	211		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	211		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	211		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	211		Information	AUDIO/COMAND																																	
E-CLASS	211		Information	ASSYST PLUS - PLUS Active Service System																																	
E-CLASS	211		Information	ASSYST Active Service System																																	
E-CLASS	211		Information	AGW - Audio gateway																																	
E-CLASS	211		Seat/Door	REDC/RWT - Rear end door control module																																	
E-CLASS	211		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
E-CLASS	211		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	211		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	211		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	211		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	211		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	211		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	211		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	211		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	211		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	207		Drive	SG-EM - Power electronics																																	
E-CLASS	207		Drive	SCR - Selective catalytic reduction	V																																
E-CLASS	207		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V					V			
E-CLASS	207		Drive	ETC - Electronic transmission control								V												V														V
E-CLASS	207		Drive	ESM - Electronic selector module																																	
E-CLASS	207		Drive	ISM - Intelligent servo module																																	
E-CLASS	207		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	207		Drive	DTR - Distronic																																	
E-CLASS	207		Drive	DSI - Direct select interface																																	
E-CLASS	207		Drive	AMG DRIVE UNIT																																	
E-CLASS	207		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	207		Chassis	Suspension																																	
E-CLASS	207		Chassis	ES - Electrical power steering																						V											
E-CLASS	207		Chassis	FWGW - Chassis gateway																																	
E-CLASS	207		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	207		Body	BNS/BMS - Battery sensor																																	
E-CLASS	207		Body	WSS - Weight sensing system																																	
E-CLASS	207		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	207		Body	SCM [MRM] - Steering column module																																	
E-CLASS	207		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	207		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
E-CLASS	207		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	207		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	207		Body	Multifunction control unit																																	
E-CLASS	207		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
E-CLASS	207		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
E-CLASS	207		Body	Headlamp-R - Headlamp control unit													V																				
E-CLASS	207		Body	Headlamp/Headlamp-L - Headlamp control unit												V												V	V								
E-CLASS	207		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	207		Body	CGW - Central gateway																																	
E-CLASS	207		Body	AHE - Trailer recognition																																	
E-CLASS	207		Body	AB - Airbag																																	
E-CLASS	207		Information	NBR-RF - Right front range radar																																	
E-CLASS	207		Information	NBR-LF - Left front range radar																																	
E-CLASS	207		Information	AVE-H - Rear audio video unit																																	
E-CLASS	207		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	207		Information	ZAN - Audio/COMAND display																																	
E-CLASS	207		Information	TV - TV tuner																																	
E-CLASS	207		Information	SOUND - Sound system																																	
E-CLASS	207		Information	SGR - Radar sensors control unit																																	
E-CLASS	207		Information	360' - Camera																																	
E-CLASS	207		Information	MFK - Multifunction camera																																	
E-CLASS	207		Information	RFK - Backup camera																																	
E-CLASS	207		Information	PTS - Parktronic system																																	
E-CLASS	207		Information	NSA - Night View Assist																																	
E-CLASS	207		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	207		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	207		Information	NAV - Navigation module																																	
E-CLASS	207		Information	MIF/UCI - Media interface																																	
E-CLASS	207		Information	ICI - InCar Internet																																	
E-CLASS	207		Information	IC - Instrument cluster							V																										
E-CLASS	207		Information	DVD player																																	
E-CLASS	207		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	207		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	207		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	207		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	207		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	207		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	207		Information	AUDIO/COMAND																																	
E-CLASS	207		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	207		Seat/Door	PSD/MSC - Sliding roof control																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
E-CLASS	207		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	207		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	207		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	207		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	207		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	207		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	207		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	212		Drive	SG-EM - Power electronics																																	
E-CLASS	212		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	212		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V					V			
E-CLASS	212		Drive	ETC - Electronic transmission control								V												V														V
E-CLASS	212		Drive	ESM - Electronic selector module																																	
E-CLASS	212		Drive	SCR - Selective catalytic reduction	V																																
E-CLASS	212		Drive	ISM - Intelligent servo module																																	
E-CLASS	212		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	212		Drive	DTR - Distronic																																	
E-CLASS	212		Drive	DSI - Direct select interface																																	
E-CLASS	212		Drive	AMG DRIVE UNIT																																	
E-CLASS	212		Chassis	ABS/ESP - Electronic stability program																													V				
E-CLASS	212		Chassis	Suspension																																	
E-CLASS	212		Chassis	ES - Electrical power steering																						V											
E-CLASS	212		Chassis	FWGW - Chassis gateway																																	
E-CLASS	212		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	212		Body	BNS/BMS - Battery sensor																																	
E-CLASS	212		Body	WSS - Weight sensing system																																	
E-CLASS	212		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	212		Body	SCM [MRM] - Steering column module																																	
E-CLASS	212		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	212		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
E-CLASS	212		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	OCP - Overhead control panel																																	
E-CLASS	212		Body	Multifunction control unit																																	
E-CLASS	212		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
E-CLASS	212		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	212		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
E-CLASS	212		Body	Headlamp-R - Headlamp control unit													V																				
E-CLASS	212		Body	Headlamp/Headlamp-L - Headlamp control unit												V												V	V								
E-CLASS	212		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	212		Body	CGW - Central gateway																																	
E-CLASS	212		Body	AHE - Trailer recognition																																	
E-CLASS	212		Body	AB - Airbag																																	
E-CLASS	212		Information	Head-up display																																	
E-CLASS	212		Information	AVE-H - Rear audio video unit																																	
E-CLASS	212		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	212		Information	ZAN - Audio/COMAND display																																	
E-CLASS	212		Information	TV - TV tuner																																	
E-CLASS	212		Information	SOUND - Sound system																																	
E-CLASS	212		Information	SGR - Radar sensors control unit																																	
E-CLASS	212		Information	360' - Camera																																	
E-CLASS	212		Information	MFK - Multifunction camera																																	
E-CLASS	212		Information	RFK - Backup camera																																	
E-CLASS	212		Information	PTS - Parktronic system																																	
E-CLASS	212		Information	NSA - Night View Assist																																	
E-CLASS	212		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	212		Information	NBR-RF - Right front range radar																																	
E-CLASS	212		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	212		Information	NBR-LF - Left front range radar																																	
E-CLASS	212		Information	NAV - Navigation module																																	
E-CLASS	212		Information	MIF/UCI - Media interface																																	
E-CLASS	212		Information	ICI - InCar Internet																																	
E-CLASS	212		Information	IC - Instrument cluster							V																										
E-CLASS	212		Information	DVD player																																	
E-CLASS	212		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	212		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	212		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	212		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	212		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	212		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	212		Information	AUDIO/COMAND																																	
E-CLASS	212		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	212		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
E-CLASS	212		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	212		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	212		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	212		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	212		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	212		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	212		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	212		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	212		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	212		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	213		Drive	SCR - Selective catalytic reduction	V																																
E-CLASS	213		Drive	DTR - Distronic																																	
E-CLASS	213		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	213		Drive	HFPM - Haptic accelerator pedal module																																	
E-CLASS	213		Drive	AMG DRIVE UNIT																																	
E-CLASS	213		Drive	PTCU - Common powertrain controller																																	
E-CLASS	213		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V					V			
E-CLASS	213		Drive	ETC - Electronic transmission control																				V													
E-CLASS	213		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	213		Chassis	AIRMATIC PLUS																																	
E-CLASS	213		Chassis	ES - Electrical power steering																																	
E-CLASS	213		Chassis	Suspension																																	
E-CLASS	213		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	213		Body	MTAS - Mobile phone cradle																																	
E-CLASS	213		Body	AHE - Trailer recognition																																	
E-CLASS	213		Body	SCM [MRM] - Steering column module																																	
E-CLASS	213		Body	RevETR-RF - Right front reversible emergency tensioning retractor																											V						
E-CLASS	213		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
E-CLASS	213		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
E-CLASS	213		Body	AB - Airbag																																	
E-CLASS	213		Body	OCP - Overhead control panel																																	
E-CLASS	213		Body	Multifunction control unit																																	
E-CLASS	213		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
E-CLASS	213		Body	SG-DDW - DC/DC converter control unit																																	
E-CLASS	213		Body	Headlamp-R - Headlamp control unit														V																			
E-CLASS	213		Body	Headlamp/Headlamp-L - Headlamp control unit			V	V							V																						
E-CLASS	213		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	213		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	213		Body	BNS/BMS - Battery sensor																																	
E-CLASS	213		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	213		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	213		Body	AML - Ambiance light																																	
E-CLASS	213		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	213		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	213		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
E-CLASS	213		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
E-CLASS	213		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	213		Seat/Door	HKS - Tailgate control																																	
E-CLASS	213		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	213		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	213		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	213		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	213		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	213		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	213		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	213		Information	TPAD - Touchpad																																	
E-CLASS	213		Information	Sound generator for exhaust system																																	
E-CLASS	213		Information	SOUND - Sound system																																	
E-CLASS	213		Information	RFK - Backup camera																																	
E-CLASS	213		Information	PTS - Parktronic system																																	
E-CLASS	213		Information	MFK - Multifunction camera																																	
E-CLASS	213		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	213		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	213		Information	SGR - Radar sensors control unit																V																	
E-CLASS	213		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
E-CLASS	213		Information	Head-up display																																	
E-CLASS	213		Information	AUDIO/COMAND																																	
E-CLASS	213		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	213		Information	ZAN - Audio/COMAND display																																	
E-CLASS	213		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	213		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	140		Drive	ASF																																	
S-CLASS	140		Drive	ERE																																	
S-CLASS	140		Drive	ME1LI																																	
S-CLASS	140		Drive	ME1RE																																	
S-CLASS	140		Drive	HFM/ME2/LH																																	
S-CLASS	140		Drive	ETC - Electronic transmission control																																	
S-CLASS	140		Drive	ISC - Idle speed control																																	
S-CLASS	140		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	140		Chassis	BAS - Brake assist																																	
S-CLASS	140		Body	PSE - Pneumatic system equipment																																	
S-CLASS	140		Body	AB - Airbag																																	
S-CLASS	140		Information	PTS - Parktronic system																																	
S-CLASS	140		Information	IC - Instrument cluster																																	
S-CLASS	140		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	220		Drive	ME/CDI/CNG - Engine control unit								V									V	V					V											
S-CLASS	220		Drive	ETC - Electronic transmission control								V																									V
S-CLASS	220		Drive	ESM - Electronic selector module																																	
S-CLASS	220		Drive	DTR - Distronic																																	
S-CLASS	220		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	220		Chassis	Suspension																																	
S-CLASS	220		Chassis	PSE - Pneumatic system equipment																																	
S-CLASS	220		Chassis	ABS/ESP - Electronic stability program																			V									V					
S-CLASS	220		Body	UCP - Upper control panel																																	
S-CLASS	220		Body	System diagnosis																																	
S-CLASS	220		Body	SCM [MRM] - Steering column module																																	
S-CLASS	220		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	220		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
S-CLASS	220		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	220		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	220		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
S-CLASS	220		Body	OCP - Overhead control panel																																	
S-CLASS	220		Body	Multifunction control unit																																	
S-CLASS	220		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	220		Body	HSW/LRH - Steering wheel heater																																	
S-CLASS	220		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	220		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	220		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	220		Body	CGW - Central gateway																																	
S-CLASS	220		Body	AHE - Trailer recognition																																	
S-CLASS	220		Body	AB - Airbag																																	
S-CLASS	220		Information	TV - TV tuner																																	
S-CLASS	220		Information	PTS - Parktronic system																																	
S-CLASS	220		Information	NAV - Navigation module																																	
S-CLASS	220		Information	IC - Instrument cluster																																	
S-CLASS	220		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	220		Information	AUDIO/COMAND																																	
S-CLASS	220		Information	AGW - Audio gateway																																	
S-CLASS	220		Seat/Door	OSB-R - Multicontour backrest rear																																	
S-CLASS	220		Seat/Door	OSB-FL - Multicontour backrest front left																																	
S-CLASS	220		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	220		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	220		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	220		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	220		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	220		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	220		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	220		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	220		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	220		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	220		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	221		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V					V			
S-CLASS	221		Drive	ETC - Electronic transmission control								V																									V
S-CLASS	221		Drive	SCR - Selective catalytic reduction	V																																
S-CLASS	221		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
S-CLASS	221		Drive	HSG - Hybrid control unit																																	
S-CLASS	221		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	221		Drive	DTR - Distronic																																	
S-CLASS	221		Chassis	ABS/ESP - Electronic stability program																												V					
S-CLASS	221		Chassis	Suspension																																	
S-CLASS	221		Chassis	ES - Electrical power steering																																	
S-CLASS	221		Chassis	EFB - Electric parking brake																																	
S-CLASS	221		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	221		Body	WSS - Weight sensing system																																	
S-CLASS	221		Body	UCP - Upper control panel																																	
S-CLASS	221		Body	System diagnosis																																	
S-CLASS	221		Body	SG-DDW - DC/DC converter control unit																																	
S-CLASS	221		Body	SCM [MRM] - Steering column module																																	
S-CLASS	221		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	221		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	221		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	OCP - Overhead control panel																																	
S-CLASS	221		Body	Multifunction control unit																																	
S-CLASS	221		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	221		Body	Headlamp-R - Headlamp control unit													V																				
S-CLASS	221		Body	Headlamp/Headlamp-L - Headlamp control unit												V											V	V									
S-CLASS	221		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	221		Body	CGW - Central gateway																																	
S-CLASS	221		Body	BNS/BMS - Battery sensor																																	
S-CLASS	221		Body	AHE - Trailer recognition																																	
S-CLASS	221		Body	AB - Airbag																																	
S-CLASS	221		Information	ZAN - Audio/COMAND display																																	
S-CLASS	221		Information	VCS - Voice control																																	
S-CLASS	221		Information	TV - TV tuner																																	
S-CLASS	221		Information	Tuner - Standard tuner																																	
S-CLASS	221		Information	SOUND - Sound system																																	
S-CLASS	221		Information	SGR - Radar sensors control unit																																	
S-CLASS	221		Information	MFK - Multifunction camera																																	
S-CLASS	221		Information	RFK - Backup camera																																	
S-CLASS	221		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
S-CLASS	221		Information	NSA - Night View Assist																																	
S-CLASS	221		Information	NBR-LF - Left front range radar																																	
S-CLASS	221		Information	NAV - Navigation module																																	
S-CLASS	221		Information	MIF/UCI - Media interface																																	
S-CLASS	221		Information	ICI - InCar Internet																																	
S-CLASS	221		Information	IC - Instrument cluster																																	
S-CLASS	221		Information	DVD player																																	
S-CLASS	221		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	221		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	221		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	221		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	221		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	221		Information	AVE-H - Rear audio video unit																																	
S-CLASS	221		Information	AUDIO/COMAND																																	
S-CLASS	221		Information	ASSYST PLUS - PLUS Active Service System																																	
S-CLASS	221		Information	ASSYST Active Service System																																	
S-CLASS	221		Seat/Door	TSG-MR - Right center door control unit																																	
S-CLASS	221		Seat/Door	TSG-ML - Left center door control unit																																	
S-CLASS	221		Seat/Door	TLC/GTO - Garage door opener																																	
S-CLASS	221		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	221		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
S-CLASS	221		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
S-CLASS	221		Seat/Door	HKS - Tailgate control																																	
S-CLASS	221		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	221		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	221		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	221		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	221		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	221		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	221		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	221		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	221		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	221		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	221		Air Conditioning	HBF - Rear control panel																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
S-CLASS	221		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	217		Drive	SCR - Selective catalytic reduction	V																																
S-CLASS	217		Drive	SG-EM - Power electronics																																	
S-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	217		Drive	DTR - Distronic																																	
S-CLASS	217		Drive	ISM - Intelligent servo module																																	
S-CLASS	217		Drive	PTCU - Common powertrain controller																																	
S-CLASS	217		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V				V			
S-CLASS	217		Drive	ETC - Electronic transmission control																				V													
S-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	217		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	217		Chassis	ES - Electrical power steering																																	
S-CLASS	217		Chassis	Suspension																																	
S-CLASS	217		Chassis	EFB - Electric parking brake																												V					
S-CLASS	217		Information	TPAD - Touchpad																																	
S-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	217		Information	360' - Camera																																	
S-CLASS	217		Information	SOUND - Sound system																																	
S-CLASS	217		Information	RFK - Backup camera																																	
S-CLASS	217		Information	SGR - Radar sensors control unit																V																	
S-CLASS	217		Information	PTS - Parktronic system																																	
S-CLASS	217		Information	NSA - Night View Assist																																	
S-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	217		Information	NBR-RF - Right front range radar																																	
S-CLASS	217		Information	NBR-LF - Left front range radar																																	
S-CLASS	217		Information	MFK - Multifunction camera																																	
S-CLASS	217		Information	Head-up display																																	
S-CLASS	217		Information	AUDIO/COMAND																																	
S-CLASS	217		Information	ZAN - Audio/COMAND display																																	
S-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	217		Information	KAB - Camera cover																																	
S-CLASS	217		Information	IC - Instrument cluster																																	
S-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	217		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
S-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																											V						
S-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	AB - Airbag																																	
S-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	217		Body	Headlamp-R - Headlamp control unit														V																			
S-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit			V	V							V																						
S-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	217		Body	BNS/BMS - Battery sensor																																	
S-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	217		Seat/Door	HKS - Tailgate control																																	
S-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
S-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	222		Drive	SCR - Selective catalytic reduction	V																																
S-CLASS	222		Drive	SG-EM - Power electronics																																	
S-CLASS	222		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	222		Drive	DTR - Distronic																																	
S-CLASS	222		Drive	ISM - Intelligent servo module																																	
S-CLASS	222		Drive	PTCU - Common powertrain controller																																	
S-CLASS	222		Drive	ME/CDI/CNG - Engine control unit										V					V						V						V				V			
S-CLASS	222		Drive	ETC - Electronic transmission control																				V													
S-CLASS	222		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	222		Chassis	ES - Electrical power steering																																	
S-CLASS	222		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	222		Chassis	Suspension																																	
S-CLASS	222		Chassis	EFB - Electric parking brake																												V					
S-CLASS	222		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
S-CLASS	222		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	222		Information	360' - Camera																																	
S-CLASS	222		Information	Sound generator for exhaust system																																	
S-CLASS	222		Information	SOUND - Sound system																																	
S-CLASS	222		Information	RFK - Backup camera																																	
S-CLASS	222		Information	SGR - Radar sensors control unit																V																	
S-CLASS	222		Information	PTS - Parktronic system																																	
S-CLASS	222		Information	NSA - Night View Assist																																	
S-CLASS	222		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	222		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	222		Information	NBR-RF - Right front range radar																																	
S-CLASS	222		Information	NBR-LF - Left front range radar																																	
S-CLASS	222		Information	MFK - Multifunction camera																																	
S-CLASS	222		Information	Head-up display																																	
S-CLASS	222		Information	AUDIO/COMAND																																	
S-CLASS	222		Information	AVE-H - Rear audio video unit																																	
S-CLASS	222		Information	ZAN - Audio/COMAND display																																	
S-CLASS	222		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	222		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	222		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	222		Information	KAB - Camera cover																																	
S-CLASS	222		Information	IC - Instrument cluster																																	
S-CLASS	222		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	222		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	222		Body	AHE - Trailer recognition																																	
S-CLASS	222		Body	SCM [MRM] - Steering column module																																	
S-CLASS	222		Body	RevETR-RF - Right front reversible emergency tensioning retractor																											V						
S-CLASS	222		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	AB - Airbag																																	
S-CLASS	222		Body	Multifunction control unit																																	
S-CLASS	222		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	222		Body	Headlamp-R - Headlamp control unit														V																			
S-CLASS	222		Body	Headlamp/Headlamp-L - Headlamp control unit			V	V							V																						
S-CLASS	222		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
S-CLASS	222		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	222		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
S-CLASS	222		Body	BNS/BMS - Battery sensor																																	
S-CLASS	222		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	222		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	222		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	222		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	222		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
S-CLASS	222		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
S-CLASS	222		Seat/Door	HKS - Tailgate control																																	
S-CLASS	222		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	222		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	222		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	222		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	222		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	222		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	222		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	222		Air Conditioning	AAC - Automatic air conditioning																																	
G-CLASS	461 - 38P Connector		Drive	EVE																																	
G-CLASS	461 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 38P Connector		Information	IC - Instrument cluster																																	
G-CLASS	461 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	461 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V				V			
G-CLASS	461 - 16P Connector		Drive	ETC - Electronic transmission control								V																									V
G-CLASS	461 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	461 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	461 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																												V					
G-CLASS	461 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	461 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	461 - 16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
G-CLASS	461 - 16P Connector		Body	CGW - Central gateway																																	
G-CLASS	461 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 16P Connector		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
G-CLASS	461 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	461 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	461 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 38P Connector		Drive	ME/CDI/CNG - Engine control unit																	V	V															
G-CLASS	463 - 38P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	463 - 38P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 38P Connector		Drive	CC - Cruise control																																	
G-CLASS	463 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	463 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 38P Connector		Information	IC - Instrument cluster																																	
G-CLASS	463 - 38P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 38P Connector		Information	APS - Auto pilot system																																	
G-CLASS	463 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V				V			
G-CLASS	463 - 16P Connector		Drive	ETC - Electronic transmission control								V																									V
G-CLASS	463 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	463 - 16P Connector		Drive	SCR - Selective catalytic reduction	V																																
G-CLASS	463 - 16P Connector		Drive	ISM - Intelligent servo module																																	
G-CLASS	463 - 16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
G-CLASS	463 - 16P Connector		Drive	DTR - Distronic																																	
G-CLASS	463 - 16P Connector		Drive	DSI - Direct select interface																																	
G-CLASS	463 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																			V									V					
G-CLASS	463 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	463 - 16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
G-CLASS	463 - 16P Connector		Body	UCP - Upper control panel																																	
G-CLASS	463 - 16P Connector		Body	SCM [MRM] - Steering column module																																	
G-CLASS	463 - 16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
G-CLASS	463 - 16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
G-CLASS	463 - 16P Connector		Body	OCP - Overhead control panel																																	
G-CLASS	463 - 16P Connector		Body	Multifunction control unit																																	
G-CLASS	463 - 16P Connector		Body	HSW/LRH - Steering wheel heater																																	
G-CLASS	463 - 16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
G-CLASS	463 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	463 - 16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
G-CLASS	463 - 16P Connector		Body	AHE - Trailer recognition																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
G-CLASS	463 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 16P Connector		Information	ZAN - Audio/COMAND display																																	
G-CLASS	463 - 16P Connector		Information	TV - TV tuner																																	
G-CLASS	463 - 16P Connector		Information	SOUND - Sound system																																	
G-CLASS	463 - 16P Connector		Information	PTS - Parktronic system																																	
G-CLASS	463 - 16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NAV - Navigation module																																	
G-CLASS	463 - 16P Connector		Information	MIF/UCI - Media interface																																	
G-CLASS	463 - 16P Connector		Information	IC - Instrument cluster							V																										
G-CLASS	463 - 16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
G-CLASS	463 - 16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
G-CLASS	463 - 16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
G-CLASS	463 - 16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
G-CLASS	463 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	463 - 16P Connector		Seat/Door	HS - Seat heater																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RR - Door control module rear right																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RL - Door control module rear left																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FR - Door control module front right																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FL - Door control module front left																																	
G-CLASS	463 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Air Conditioning	AAC - Automatic air conditioning																																	
GLA-CLASS	156		Drive	VG - Transfer case																																	
GLA-CLASS	156		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V					V			
GLA-CLASS	156		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLA-CLASS	156		Drive	ETC - Electronic transmission control																				V													
GLA-CLASS	156		Drive	DTR - Distronic																																	
GLA-CLASS	156		Drive	DSI - Direct select interface																																	
GLA-CLASS	156		Drive	PTCU - Common powertrain controller																																	
GLA-CLASS	156		Chassis	ABS/ESP - Electronic stability program																																	
GLA-CLASS	156		Chassis	ES - Electrical power steering																					V												
GLA-CLASS	156		Chassis	EFB - Electric parking brake																												V					
GLA-CLASS	156		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
GLA-CLASS	156		Body	SG-AWF - Collision prevention assist																																	
GLA-CLASS	156		Body	SCM [MRM] - Steering column module																																	
GLA-CLASS	156		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
GLA-CLASS	156		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	Multifunction control unit																																	
GLA-CLASS	156		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLA-CLASS	156		Body	Headlamp/Headlamp-L - Headlamp control unit												V											V	V									
GLA-CLASS	156		Body	EZS/EIS - Electronic ignition lock																																	
GLA-CLASS	156		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLA-CLASS	156		Body	AHE - Trailer recognition																																	
GLA-CLASS	156		Body	AB - Airbag																																	
GLA-CLASS	156		Information	Head-up display																																	
GLA-CLASS	156		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLA-CLASS	156		Information	KAB - Camera cover																																	
GLA-CLASS	156		Information	ZAN - Audio/COMAND display																																	
GLA-CLASS	156		Information	TV - TV tuner																																	
GLA-CLASS	156		Information	SOUND - Sound system																																	
GLA-CLASS	156		Information	RFK - Backup camera																																	
GLA-CLASS	156		Information	MFK - Multifunction camera																																	
GLA-CLASS	156		Information	PTS - Parktronic system																																	
GLA-CLASS	156		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLA-CLASS	156		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLA-CLASS	156		Information	NAV - Navigation module																																	
GLA-CLASS	156		Information	MIF/UCI - Media interface																																	
GLA-CLASS	156		Information	IC - Instrument cluster							V																										
GLA-CLASS	156		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLA-CLASS	156		Information	DAB/SDAR - Digital/Satellite radio																																	
GLA-CLASS	156		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLA-CLASS	156		Information	AUDIO/COMAND																																	
GLA-CLASS	156		Seat/Door	HKS - Tailgate control																																	
GLA-CLASS	156		Seat/Door	PSD/MSC - Sliding roof control																																	
GLA-CLASS	156		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLA-CLASS	156		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLA-CLASS	156		Seat/Door	DCM-FR - Door control module front right																																	
GLA-CLASS	156		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
GLA-CLASS	156		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLA-CLASS	156		Air Conditioning	AAC - Automatic air conditioning																																	
GLK-CLASS	204		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V				V			
GLK-CLASS	204		Drive	ETC - Electronic transmission control								V												V													V
GLK-CLASS	204		Drive	ESM - Electronic selector module																																	
GLK-CLASS	204		Drive	SCR - Selective catalytic reduction	V																																
GLK-CLASS	204		Drive	PTCU - Common powertrain controller																																	
GLK-CLASS	204		Drive	ISM - Intelligent servo module																																	
GLK-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
GLK-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLK-CLASS	204		Drive	DTR - Distronic																																	
GLK-CLASS	204		Drive	AMG DRIVE UNIT																																	
GLK-CLASS	204		Chassis	ABS/ESP - Electronic stability program																												V					
GLK-CLASS	204		Chassis	Suspension																																	
GLK-CLASS	204		Chassis	ES - Electrical power steering																					V												
GLK-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
GLK-CLASS	204		Body	WSS - Weight sensing system																																	
GLK-CLASS	204		Body	SCM [MRM] - Steering column module																																	
GLK-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLK-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
GLK-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	OCP - Overhead control panel																																	
GLK-CLASS	204		Body	Multifunction control unit																																	
GLK-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLK-CLASS	204		Body	Headlamp-R - Headlamp control unit													V																				
GLK-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit												V											V	V									
GLK-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	
GLK-CLASS	204		Body	CGW - Central gateway																																	
GLK-CLASS	204		Body	AHE - Trailer recognition																																	
GLK-CLASS	204		Body	AB - Airbag																																	
GLK-CLASS	204		Information	Head-up display																																	
GLK-CLASS	204		Information	AVE-H - Rear audio video unit																																	
GLK-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLK-CLASS	204		Information	ZAN - Audio/COMAND display																																	
GLK-CLASS	204		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
GLK-CLASS	204		Information	Sound generator for exhaust system																																	
GLK-CLASS	204		Information	SOUND - Sound system																																	
GLK-CLASS	204		Information	SGR - Radar sensors control unit																																	
GLK-CLASS	204		Information	360' - Camera																																	
GLK-CLASS	204		Information	MFK - Multifunction camera																																	
GLK-CLASS	204		Information	RFK - Backup camera																																	
GLK-CLASS	204		Information	PTS - Parktronic system																																	
GLK-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLK-CLASS	204		Information	NBR-RF - Right front range radar																																	
GLK-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLK-CLASS	204		Information	NBR-LF - Left front range radar																																	
GLK-CLASS	204		Information	NAV - Navigation module																																	
GLK-CLASS	204		Information	MIF/UCI - Media interface																																	
GLK-CLASS	204		Information	ICI - InCar Internet																																	
GLK-CLASS	204		Information	IC - Instrument cluster							V																										
GLK-CLASS	204		Information	DVD player																																	
GLK-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLK-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
GLK-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
GLK-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
GLK-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GLK-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLK-CLASS	204		Information	AUDIO/COMAND																																	
GLK-CLASS	204		Information	AMG Performance Media																																	
GLK-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
GLK-CLASS	204		Seat/Door	HKS - Tailgate control																																	
GLK-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLK-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLK-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
GLK-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
GLK-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
GLK-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
GLK-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLK-CLASS	204		Air Conditioning	AAC - Automatic air conditioning																																	
GLC-CLASS	253		Drive	SCR - Selective catalytic reduction	V																																
GLC-CLASS	253		Drive	SG-EM - Power electronics																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
GLC-CLASS	253		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLC-CLASS	253		Drive	DTR - Distronic																V																	
GLC-CLASS	253		Drive	ISM - Intelligent servo module																																	
GLC-CLASS	253		Drive	PTCU - Common powertrain controller																																	
GLC-CLASS	253		Drive	ME/CDI/CNG - Engine control unit									V					V						V					V				V				
GLC-CLASS	253		Drive	ETC - Electronic transmission control																			V														
GLC-CLASS	253		Chassis	TPM - Tire pressure monitor																																	
GLC-CLASS	253		Chassis	AIRMATIC PLUS																																	
GLC-CLASS	253		Chassis	ES - Electrical power steering																																	
GLC-CLASS	253		Chassis	Suspension																																	
GLC-CLASS	253		Chassis	ABS/ESP - Electronic stability program																																	
GLC-CLASS	253		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLC-CLASS	253		Body	AHE - Trailer recognition																																	
GLC-CLASS	253		Body	SCM [MRM] - Steering column module																																	
GLC-CLASS	253		Body	RevETR-RF - Right front reversible emergency tensioning retractor																											V						
GLC-CLASS	253		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	AB - Airbag																																	
GLC-CLASS	253		Body	Multifunction control unit																																	
GLC-CLASS	253		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLC-CLASS	253		Body	Headlamp-R - Headlamp control unit														V																			
GLC-CLASS	253		Body	Headlamp/Headlamp-L - Headlamp control unit			V	V							V																						
GLC-CLASS	253		Body	SG-AWF - Collision prevention assist																																	
GLC-CLASS	253		Body	EZS/EIS - Electronic ignition lock																																	
GLC-CLASS	253		Body	BNS/BMS - Battery sensor																																	
GLC-CLASS	253		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLC-CLASS	253		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLC-CLASS	253		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLC-CLASS	253		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLC-CLASS	253		Seat/Door	PSD/MSC - Sliding roof control																																	
GLC-CLASS	253		Seat/Door	HKS - Tailgate control																																	
GLC-CLASS	253		Seat/Door	DCM-RR - Door control module rear right																																	
GLC-CLASS	253		Seat/Door	DCM-RL - Door control module rear left																																	
GLC-CLASS	253		Seat/Door	DCM-FR - Door control module front right																																	
GLC-CLASS	253		Seat/Door	DCM-FL - Door control module front left																																	
GLC-CLASS	253		Information	TPAD - Touchpad																																	
GLC-CLASS	253		Information	DAB/SDAR - Digital/Satellite radio																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
GLC-CLASS	253		Information	360' - Camera																																	
GLC-CLASS	253		Information	Sound generator for exhaust system																																	
GLC-CLASS	253		Information	SOUND - Sound system																																	
GLC-CLASS	253		Information	RFK - Backup camera																																	
GLC-CLASS	253		Information	SGR - Radar sensors control unit																V																	
GLC-CLASS	253		Information	PTS - Parktronic system																																	
GLC-CLASS	253		Information	NBR-RF - Right front range radar																																	
GLC-CLASS	253		Information	NBR-LF - Left front range radar																																	
GLC-CLASS	253		Information	MFK - Multifunction camera																																	
GLC-CLASS	253		Information	IC - Instrument cluster																																	
GLC-CLASS	253		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLC-CLASS	253		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLC-CLASS	253		Information	Head-up display																																	
GLC-CLASS	253		Information	AUDIO/COMAND																																	
GLC-CLASS	253		Information	SG-MSND - Engine sound																																	
GLC-CLASS	253		Information	ZAN - Audio/COMAND display																																	
GLC-CLASS	253		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLC-CLASS	253		Information	KAB - Camera cover																																	
GLC-CLASS	253		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLC-CLASS	253		Information	AMG Performance Media																																	
GLC-CLASS	253		Air Conditioning	AAC - Automatic air conditioning																																	
GLE-CLASS	292		Drive	SCR - Selective catalytic reduction	V																																
GLE-CLASS	292		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLE-CLASS	292		Drive	ISM - Intelligent servo module																																	
GLE-CLASS	292		Drive	DTR - Distronic																																	
GLE-CLASS	292		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V				V			
GLE-CLASS	292		Drive	ETC - Electronic transmission control								V												V													V
GLE-CLASS	292		Chassis	TPM - Tire pressure monitor																																	
GLE-CLASS	292		Chassis	FWGW - Chassis gateway																																	
GLE-CLASS	292		Chassis	ABS/ESP - Electronic stability program																												V					
GLE-CLASS	292		Chassis	ES - Electrical power steering																					V												
GLE-CLASS	292		Chassis	EFB - Electric parking brake																											V						
GLE-CLASS	292		Chassis	Suspension																																	
GLE-CLASS	292		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLE-CLASS	292		Body	AHE - Trailer recognition																																	
GLE-CLASS	292		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
GLE-CLASS	292		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLE-CLASS	292		Body	AB - Airbag																																	
GLE-CLASS	292		Body	Multifunction control unit																																	
GLE-CLASS	292		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLE-CLASS	292		Body	Headlamp-R - Headlamp control unit													V																				
GLE-CLASS	292		Body	Headlamp/Headlamp-L - Headlamp control unit												V											V	V									
GLE-CLASS	292		Body	SG-AWF - Collision prevention assist																																	
GLE-CLASS	292		Body	EZS/EIS - Electronic ignition lock																																	
GLE-CLASS	292		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
GLE-CLASS	292		Information	TPAD - Touchpad																																	
GLE-CLASS	292		Information	DAB/SDAR - Digital/Satellite radio																																	
GLE-CLASS	292		Information	360' - Camera																																	
GLE-CLASS	292		Information	SOUND - Sound system																																	
GLE-CLASS	292		Information	RFK - Backup camera																																	
GLE-CLASS	292		Information	SGR - Radar sensors control unit																																	
GLE-CLASS	292		Information	PTS - Parktronic system																																	
GLE-CLASS	292		Information	MFK - Multifunction camera																																	
GLE-CLASS	292		Information	NBR-RF - Right front range radar																																	
GLE-CLASS	292		Information	NBR-LF - Left front range radar																																	
GLE-CLASS	292		Information	IC - Instrument cluster							V																										
GLE-CLASS	292		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLE-CLASS	292		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLE-CLASS	292		Information	Head-up display																																	
GLE-CLASS	292		Information	AUDIO/COMAND																																	
GLE-CLASS	292		Information	AVE-H - Rear audio video unit																																	
GLE-CLASS	292		Information	DVD player																																	
GLE-CLASS	292		Information	SG-MSND - Engine sound																																	
GLE-CLASS	292		Information	ZAN - Audio/COMAND display																																	
GLE-CLASS	292		Information	D-FOR - Display in right rear passenger																																	
GLE-CLASS	292		Information	D-FOL - Display in left rear passenger																																	
GLE-CLASS	292		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLE-CLASS	292		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLE-CLASS	292		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLE-CLASS	292		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
GLE-CLASS	292		Seat/Door	PSD/MSC - Sliding roof control																																	
GLE-CLASS	292		Seat/Door	HKS - Tailgate control																																	
GLE-CLASS	292		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DCM-RR - Door control module rear right																																	
GLE-CLASS	292		Seat/Door	DCM-RL - Door control module rear left																																	
GLE-CLASS	292		Seat/Door	DCM-FR - Door control module front right																																	
GLE-CLASS	292		Seat/Door	DCM-FL - Door control module front left																																	
GLE-CLASS	292		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLE-CLASS	292		Air Conditioning	HBF - Rear control panel																																	
GLE-CLASS	292		Air Conditioning	AAC - Automatic air conditioning																																	
GL-CLASS	164		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V				V			
GL-CLASS	164		Drive	ETC - Electronic transmission control								V												V													V
GL-CLASS	164		Drive	VG - Transfer case																																	
GL-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
GL-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
GL-CLASS	164		Drive	SCR - Selective catalytic reduction	V																																
GL-CLASS	164		Drive	ISM - Intelligent servo module																																	
GL-CLASS	164		Drive	HSG - Hybrid control unit																																	
GL-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
GL-CLASS	164		Drive	DTR - Distronic																																	
GL-CLASS	164		Chassis	ABS/ESP - Electronic stability program																												V					
GL-CLASS	164		Chassis	Suspension																																	
GL-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
GL-CLASS	164		Chassis	ES - Electrical power steering																																	
GL-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	164		Body	WSS - Weight sensing system																																	
GL-CLASS	164		Body	UCP - Upper control panel																																	
GL-CLASS	164		Body	System diagnosis																																	
GL-CLASS	164		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GL-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
GL-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
GL-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	164		Body	CGW - Central gateway																																	
GL-CLASS	164		Body	AB - Airbag																																	
GL-CLASS	164		Information	TV - TV tuner																																	
GL-CLASS	164		Information	SOUND - Sound system																																	
GL-CLASS	164		Information	RFK - Backup camera																																	
GL-CLASS	164		Information	PTS - Parktronic system																																	
GL-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	164		Information	NAV - Navigation module																																	
GL-CLASS	164		Information	MIF/UCI - Media interface																																	
GL-CLASS	164		Information	IC - Instrument cluster																																	
GL-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GL-CLASS	164		Information	CM - Compass module																																	
GL-CLASS	164		Information	AVE-H - Rear audio video unit																																	
GL-CLASS	164		Information	AUDIO/COMAND																																	
GL-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
GL-CLASS	164		Information	ASSYST Active Service System																																	
GL-CLASS	164		Information	AGW - Audio gateway																																	
GL-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
GL-CLASS	164		Seat/Door	HS - Seat heater																																	
GL-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
GL-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
GL-CLASS	164		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GL-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
GL-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
GL-CLASS	166		Drive	SG-EM - Power electronics																																	
GL-CLASS	166		Drive	PTCU - Common powertrain controller																																	
GL-CLASS	166		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V				V			
GL-CLASS	166		Drive	ETC - Electronic transmission control								V												V													V
GL-CLASS	166		Drive	VG - Transfer case																																	
GL-CLASS	166		Drive	SCR - Selective catalytic reduction	V																																
GL-CLASS	166		Drive	ISM - Intelligent servo module																																	
GL-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	166		Drive	DTR - Distronic																																	
GL-CLASS	166		Chassis	ABS/ESP - Electronic stability program																												V					
GL-CLASS	166		Chassis	Suspension																																	
GL-CLASS	166		Chassis	ES - Electrical power steering																					V												
GL-CLASS	166		Chassis	EFB - Electric parking brake																												V					
GL-CLASS	166		Chassis	FWGW - Chassis gateway																																	
GL-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
GL-CLASS	166		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
GL-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	Multifunction control unit																																	
GL-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	166		Body	Headlamp-R - Headlamp control unit													V																				
GL-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit												V												V	V								
GL-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GL-CLASS	166		Body	AHE - Trailer recognition																																	
GL-CLASS	166		Body	AB - Airbag																																	
GL-CLASS	166		Information	Sound generator for exhaust system																																	
GL-CLASS	166		Information	Head-up display																																	
GL-CLASS	166		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
GL-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GL-CLASS	166		Information	ZAN - Audio/COMAND display																																	
GL-CLASS	166		Information	TV - TV tuner																																	
GL-CLASS	166		Information	SOUND - Sound system																																	
GL-CLASS	166		Information	SGR - Radar sensors control unit																																	
GL-CLASS	166		Information	360' - Camera																																	
GL-CLASS	166		Information	RFK - Backup camera																																	
GL-CLASS	166		Information	MFK - Multifunction camera																																	
GL-CLASS	166		Information	PTS - Parktronic system																																	
GL-CLASS	166		Information	NSA - Night View Assist																																	
GL-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	166		Information	NBR-RF - Right front range radar																																	
GL-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	166		Information	NBR-LF - Left front range radar																																	
GL-CLASS	166		Information	NAV - Navigation module																																	
GL-CLASS	166		Information	MIF/UCI - Media interface																																	
GL-CLASS	166		Information	IC - Instrument cluster							V																										
GL-CLASS	166		Information	DVD player																																	
GL-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GL-CLASS	166		Information	AUDIO/COMAND																																	
GL-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
GL-CLASS	166		Seat/Door	HKS - Tailgate control																																	
GL-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
GL-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
GL-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
GL-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
GL-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
GL-CLASS	166		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	163		Drive	ME/CDI/CNG - Engine control unit																	V	V															
M-CLASS	163		Drive	ETC - Electronic transmission control								V																									V
M-CLASS	163		Drive	ESM - Electronic selector module																																	
M-CLASS	163		Drive	VG - Transfer case																																	
M-CLASS	163		Chassis	ABS/ESP - Electronic stability program																			V										V				
M-CLASS	163		Chassis	VP - Vacuum pump brake booster																																	
M-CLASS	163		Chassis	BAS - Brake assist																																	
M-CLASS	163		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	163		Body	AB - Airbag																																	
M-CLASS	163		Body	AAM - All activity module																																	
M-CLASS	163		Information	PTS - Parktronic system																																	
M-CLASS	163		Information	IC - Instrument cluster																																	
M-CLASS	163		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	163		Information	AUDIO/COMAND																																	
M-CLASS	163		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	163		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V					V			
M-CLASS	164		Drive	ETC - Electronic transmission control								V												V													V
M-CLASS	164		Drive	VG - Transfer case																																	
M-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
M-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
M-CLASS	164		Drive	SCR - Selective catalytic reduction	V																																
M-CLASS	164		Drive	ISM - Intelligent servo module																																	
M-CLASS	164		Drive	HSG - Hybrid control unit																																	
M-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
M-CLASS	164		Drive	DTR - Distronic																																	
M-CLASS	164		Chassis	ABS/ESP - Electronic stability program																													V				
M-CLASS	164		Chassis	Suspension																																	
M-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
M-CLASS	164		Chassis	ES - Electrical power steering																																	
M-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	164		Body	WSS - Weight sensing system																																	
M-CLASS	164		Body	UCP - Upper control panel																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
M-CLASS	164		Body	System diagnosis																																	
M-CLASS	164		Body	SCM [MRM] - Steering column module																																	
M-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
M-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	OCP - Overhead control panel																																	
M-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
M-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	164		Body	CGW - Central gateway																																	
M-CLASS	164		Body	AB - Airbag																																	
M-CLASS	164		Information	TV - TV tuner																																	
M-CLASS	164		Information	SOUND - Sound system																																	
M-CLASS	164		Information	RFK - Backup camera																																	
M-CLASS	164		Information	PTS - Parktronic system																																	
M-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	164		Information	NAV - Navigation module																																	
M-CLASS	164		Information	MIF/UCI - Media interface																																	
M-CLASS	164		Information	IC - Instrument cluster																																	
M-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
M-CLASS	164		Information	CM - Compass module																																	
M-CLASS	164		Information	AVE-H - Rear audio video unit																																	
M-CLASS	164		Information	AUDIO/COMAND																																	
M-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
M-CLASS	164		Information	ASSYST Active Service System																																	
M-CLASS	164		Information	AGW - Audio gateway																																	
M-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
M-CLASS	164		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
M-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
M-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	164		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
M-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	166		Drive	SG-EM - Power electronics																																	
M-CLASS	166		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V				V			
M-CLASS	166		Drive	ETC - Electronic transmission control								V											V														V
M-CLASS	166		Drive	VG - Transfer case																																	
M-CLASS	166		Drive	SCR - Selective catalytic reduction	V																																
M-CLASS	166		Drive	PTCU - Common powertrain controller																																	
M-CLASS	166		Drive	ISM - Intelligent servo module																																	
M-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	166		Drive	DTR - Distronic																																	
M-CLASS	166		Chassis	ABS/ESP - Electronic stability program																												V					
M-CLASS	166		Chassis	Suspension																																	
M-CLASS	166		Chassis	ES - Electrical power steering																					V												
M-CLASS	166		Chassis	EFB - Electric parking brake																												V					
M-CLASS	166		Chassis	FWGW - Chassis gateway																																	
M-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
M-CLASS	166		Body	SCM [MRM] - Steering column module																																	
M-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
M-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	Multifunction control unit																																	
M-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	166		Body	Headlamp-R - Headlamp control unit													V																				
M-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit												V												V	V								

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
M-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
M-CLASS	166		Body	AHE - Trailer recognition																																	
M-CLASS	166		Body	AB - Airbag																																	
M-CLASS	166		Information	Sound generator for exhaust system																																	
M-CLASS	166		Information	Head-up display																																	
M-CLASS	166		Information	AVE-H - Rear audio video unit																																	
M-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
M-CLASS	166		Information	ZAN - Audio/COMAND display																																	
M-CLASS	166		Information	TV - TV tuner																																	
M-CLASS	166		Information	SOUND - Sound system																																	
M-CLASS	166		Information	SGR - Radar sensors control unit																																	
M-CLASS	166		Information	360' - Camera																																	
M-CLASS	166		Information	RFK - Backup camera																																	
M-CLASS	166		Information	MFK - Multifunction camera																																	
M-CLASS	166		Information	PTS - Parktronic system																																	
M-CLASS	166		Information	NSA - Night View Assist																																	
M-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	166		Information	NBR-RF - Right front range radar																																	
M-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	166		Information	NBR-LF - Left front range radar																																	
M-CLASS	166		Information	NAV - Navigation module																																	
M-CLASS	166		Information	MIF/UCI - Media interface																																	
M-CLASS	166		Information	IC - Instrument cluster							V																										
M-CLASS	166		Information	DVD player																																	
M-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
M-CLASS	166		Information	AUDIO/COMAND																																	
M-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
M-CLASS	166		Seat/Door	HKS - Tailgate control																																	
M-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
M-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
M-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
M-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
M-CLASS	166		Air Conditioning	AAC - Automatic air conditioning																																	
R-CLASS	251		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V					V			
R-CLASS	251		Drive	ETC - Electronic transmission control								V																									V
R-CLASS	251		Drive	SCR - Selective catalytic reduction	V																																
R-CLASS	251		Drive	ISM - Intelligent servo module																																	
R-CLASS	251		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
R-CLASS	251		Drive	DTR - Distronic																																	
R-CLASS	251		Chassis	ABS/ESP - Electronic stability program																													V				
R-CLASS	251		Chassis	Suspension																																	
R-CLASS	251		Chassis	ES - Electrical power steering																																	
R-CLASS	251		Chassis	TPM - Tire pressure monitor																																	
R-CLASS	251		Body	WSS - Weight sensing system																																	
R-CLASS	251		Body	UCP - Upper control panel																																	
R-CLASS	251		Body	System diagnosis																																	
R-CLASS	251		Body	SCM [MRM] - Steering column module																																	
R-CLASS	251		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
R-CLASS	251		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
R-CLASS	251		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	OCP - Overhead control panel																																	
R-CLASS	251		Body	LCP/HBF - Lower/Rear control panel																																	
R-CLASS	251		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
R-CLASS	251		Body	Headlamp-R - Headlamp control unit													V																				
R-CLASS	251		Body	Headlamp/Headlamp-L - Headlamp control unit												V												V	V								
R-CLASS	251		Body	EZS/EIS - Electronic ignition lock																																	
R-CLASS	251		Body	CGW - Central gateway																																	
R-CLASS	251		Body	AB - Airbag																																	
R-CLASS	251		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
R-CLASS	251		Information	SOUND - Sound system																																	
R-CLASS	251		Information	RFK - Backup camera																																	
R-CLASS	251		Information	PTS - Parktronic system																																	
R-CLASS	251		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
R-CLASS	251		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
R-CLASS	251		Information	NAV - Navigation module																																	
R-CLASS	251		Information	MIF/UCI - Media interface																																	
R-CLASS	251		Information	IC - Instrument cluster																																	
R-CLASS	251		Information	DTA - Mbrace or TELEAID/GPS Box																																	
R-CLASS	251		Information	D-FOR - Display in right rear passenger																																	
R-CLASS	251		Information	D-FOL - Display in left rear passenger																																	
R-CLASS	251		Information	DAB/SDAR - Digital/Satellite radio																																	
R-CLASS	251		Information	CTEL/TEL - Cellular/Mobile telephone																																	
R-CLASS	251		Information	CM - Compass module																																	
R-CLASS	251		Information	AVE-H - Rear audio video unit																																	
R-CLASS	251		Information	AUDIO/COMAND																																	
R-CLASS	251		Information	ASSYST PLUS - PLUS Active Service System																																	
R-CLASS	251		Information	ASSYST Active Service System																																	
R-CLASS	251		Information	AGW - Audio gateway																																	
R-CLASS	251		Seat/Door	REDC/RWT - Rear end door control module																																	
R-CLASS	251		Seat/Door	HS - Seat heater																																	
R-CLASS	251		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
R-CLASS	251		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
R-CLASS	251		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
R-CLASS	251		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DCM-FR - Door control module front right																																	
R-CLASS	251		Seat/Door	DCM-FL - Door control module front left																																	
R-CLASS	251		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
R-CLASS	251		Air Conditioning	AAC - Automatic air conditioning																																	
CLA-CLASS	117		Drive	VG - Transfer case																																	
CLA-CLASS	117		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V					V		
CLA-CLASS	117		Drive	ETC - Electronic transmission control																				V													
CLA-CLASS	117		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLA-CLASS	117		Drive	DTR - Distronic																																	
CLA-CLASS	117		Drive	DSI - Direct select interface																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
CLA-CLASS	117		Drive	PTCU - Common powertrain controller																																	
CLA-CLASS	117		Chassis	ABS/ESP - Electronic stability program																																	
CLA-CLASS	117		Chassis	ES - Electrical power steering																						V											
CLA-CLASS	117		Chassis	EFB - Electric parking brake																												V					
CLA-CLASS	117		Chassis	TPM - Tire pressure monitor																																	
CLA-CLASS	117		Body	SG-AWF - Collision prevention assist																																	
CLA-CLASS	117		Body	SCM [MRM] - Steering column module																																	
CLA-CLASS	117		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
CLA-CLASS	117		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	Multifunction control unit																																	
CLA-CLASS	117		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLA-CLASS	117		Body	Headlamp/Headlamp-L - Headlamp control unit												V												V	V								
CLA-CLASS	117		Body	EZS/EIS - Electronic ignition lock																																	
CLA-CLASS	117		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CLA-CLASS	117		Body	AHE - Trailer recognition																																	
CLA-CLASS	117		Body	AB - Airbag																																	
CLA-CLASS	117		Information	Head-up display																																	
CLA-CLASS	117		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLA-CLASS	117		Information	KAB - Camera cover																																	
CLA-CLASS	117		Information	ZAN - Audio/COMAND display																																	
CLA-CLASS	117		Information	TV - TV tuner																																	
CLA-CLASS	117		Information	SOUND - Sound system																																	
CLA-CLASS	117		Information	RFK - Backup camera																																	
CLA-CLASS	117		Information	MFK - Multifunction camera																																	
CLA-CLASS	117		Information	PTS - Parktronic system																																	
CLA-CLASS	117		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLA-CLASS	117		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLA-CLASS	117		Information	NAV - Navigation module																																	
CLA-CLASS	117		Information	MIF/UCI - Media interface																																	
CLA-CLASS	117		Information	IC - Instrument cluster							V																										
CLA-CLASS	117		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLA-CLASS	117		Information	DAB/SDAR - Digital/Satellite radio																																	
CLA-CLASS	117		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLA-CLASS	117		Information	AUDIO/COMAND																																	
CLA-CLASS	117		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
CLA-CLASS	117		Seat/Door	PSD/MSC - Sliding roof control																																	
CLA-CLASS	117		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLA-CLASS	117		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLA-CLASS	117		Seat/Door	DCM-FR - Door control module front right																																	
CLA-CLASS	117		Seat/Door	DCM-FL - Door control module front left																																	
CLA-CLASS	117		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLA-CLASS	117		Air Conditioning	AAC - Automatic air conditioning																																	
CLK-CLASS	208		Drive	ME/CDI/CNG - Engine control unit																	V	V															
CLK-CLASS	208		Drive	ETC - Electronic transmission control								V																									V
CLK-CLASS	208		Drive	ESM - Electronic selector module																																	
CLK-CLASS	208		Chassis	PSE - Pneumatic system equipment																																	
CLK-CLASS	208		Chassis	ABS/ESP - Electronic stability program																			V										V				
CLK-CLASS	208		Chassis	VP - Vacuum pump brake booster																																	
CLK-CLASS	208		Chassis	BAS - Brake assist																																	
CLK-CLASS	208		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	208		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	208		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	208		Body	OCP - Overhead control panel																																	
CLK-CLASS	208		Body	AB - Airbag																																	
CLK-CLASS	208		Information	TV - TV tuner																																	
CLK-CLASS	208		Information	PTS - Parktronic system																																	
CLK-CLASS	208		Information	NAV - Navigation module																																	
CLK-CLASS	208		Information	IC - Instrument cluster																																	
CLK-CLASS	208		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	208		Information	AUDIO/COMAND																																	
CLK-CLASS	208		Information	APS - Auto pilot system																																	
CLK-CLASS	208		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	208		Air Conditioning	AAC - Automatic air conditioning																																	
CLK-CLASS	208		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	208		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	208		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	208		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Drive	ME/CDI/CNG - Engine control unit								V									V	V					V										
CLK-CLASS	209		Drive	ETC - Electronic transmission control								V																									V
CLK-CLASS	209		Drive	ESM - Electronic selector module																																	
CLK-CLASS	209		Drive	DTR - Distronic																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
CLK-CLASS	209		Chassis	ABS/ESP - Electronic stability program																													V				
CLK-CLASS	209		Chassis	TPM - Tire pressure monitor																																	
CLK-CLASS	209		Body	WSS - Weight sensing system																																	
CLK-CLASS	209		Body	UCP - Upper control panel																																	
CLK-CLASS	209		Body	SCM [MRM] - Steering column module																																	
CLK-CLASS	209		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLK-CLASS	209		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	209		Body	RCM - Rear control module																																V	
CLK-CLASS	209		Body	OCP - Overhead control panel																																	
CLK-CLASS	209		Body	Multifunction control unit																																	
CLK-CLASS	209		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	209		Body	Headlamp-R - Headlamp control unit																																	
CLK-CLASS	209		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLK-CLASS	209		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	209		Body	BNS/BMS - Battery sensor																																	
CLK-CLASS	209		Body	AHE - Trailer recognition																																	
CLK-CLASS	209		Body	AB - Airbag																																	
CLK-CLASS	209		Information	TV - TV tuner																																	
CLK-CLASS	209		Information	PTS - Parktronic system																																	
CLK-CLASS	209		Information	NAV - Navigation module																																	
CLK-CLASS	209		Information	IC - Instrument cluster																																	
CLK-CLASS	209		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	209		Information	AUDIO/COMAND																																	
CLK-CLASS	209		Information	AGW - Audio gateway																																	
CLK-CLASS	209		Seat/Door	RVC/VDS - Convertible roof control																																V	
CLK-CLASS	209		Seat/Door	REDC/RWT - Rear end door control module																																	
CLK-CLASS	209		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	209		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	209		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	209		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	209		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	219		Drive	ME/CDI/CNG - Engine control unit								V									V	V					V										
CLS-CLASS	219		Drive	ETC - Electronic transmission control								V																									V
CLS-CLASS	219		Drive	ESM - Electronic selector module																																	
CLS-CLASS	219		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
CLS-CLASS	219		Drive	DTR - Distronic																																	
CLS-CLASS	219		Chassis	ABS/ESP - Electronic stability program																													V				
CLS-CLASS	219		Chassis	Suspension																																	
CLS-CLASS	219		Chassis	SBC - Sensotronic Brake Control																														V			
CLS-CLASS	219		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	219		Body	WSS - Weight sensing system																																	
CLS-CLASS	219		Body	UCP - Upper control panel																																	
CLS-CLASS	219		Body	System diagnosis																																	
CLS-CLASS	219		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	219		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	219		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CLS-CLASS	219		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLS-CLASS	219		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	OCP - Overhead control panel																																	
CLS-CLASS	219		Body	LCP/HBF - Lower/Rear control panel																																	
CLS-CLASS	219		Body	LAE [LAA] - Loading floor automatically extendable																																	
CLS-CLASS	219		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	219		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	219		Body	CGW - Central gateway																																	
CLS-CLASS	219		Body	BNS/BMS - Battery sensor																																	
CLS-CLASS	219		Body	AB - Airbag																																	
CLS-CLASS	219		Information	TV - TV tuner																																	
CLS-CLASS	219		Information	SOUND - Sound system																																	
CLS-CLASS	219		Information	PTS - Parktronic system																																	
CLS-CLASS	219		Information	MIF/UCI - Media interface																																	
CLS-CLASS	219		Information	IC - Instrument cluster																																	
CLS-CLASS	219		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	219		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	219		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	219		Information	AUDIO/COMAND																																	
CLS-CLASS	219		Information	ASSYST PLUS - PLUS Active Service System																																	
CLS-CLASS	219		Information	ASSYST Active Service System																																	
CLS-CLASS	219		Information	AGW - Audio gateway																																	
CLS-CLASS	219		Seat/Door	REDC/RWT - Rear end door control module																																	
CLS-CLASS	219		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
CLS-CLASS	219		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	219		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	219		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	219		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	219		Seat/Door	DCM-RL - Door control module rear left																																	
CLS-CLASS	219		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	219		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	219		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	219		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	218		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V					V			
CLS-CLASS	218		Drive	ETC - Electronic transmission control								V												V														V
CLS-CLASS	218		Drive	ESM - Electronic selector module																																	
CLS-CLASS	218		Drive	SCR - Selective catalytic reduction	V																																
CLS-CLASS	218		Drive	ISM - Intelligent servo module																																	
CLS-CLASS	218		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLS-CLASS	218		Drive	DTR - Distronic																																	
CLS-CLASS	218		Drive	DSI - Direct select interface																																	
CLS-CLASS	218		Drive	AMG DRIVE UNIT																																	
CLS-CLASS	218		Chassis	ABS/ESP - Electronic stability program																																	
CLS-CLASS	218		Chassis	Suspension																																	
CLS-CLASS	218		Chassis	ES - Electrical power steering																						V											
CLS-CLASS	218		Chassis	FWGW - Chassis gateway																																	
CLS-CLASS	218		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	218		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
CLS-CLASS	218		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
CLS-CLASS	218		Body	WSS - Weight sensing system																																	
CLS-CLASS	218		Body	SG-AWF - Collision prevention assist																																	
CLS-CLASS	218		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	218		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	218		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
CLS-CLASS	218		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	OCP - Overhead control panel																																	
CLS-CLASS	218		Body	Multifunction control unit																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
CLS-CLASS	218		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLS-CLASS	218		Body	HSW/LRH - Steering wheel heater																																	
CLS-CLASS	218		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
CLS-CLASS	218		Body	Headlamp-R - Headlamp control unit													V																				
CLS-CLASS	218		Body	Headlamp/Headlamp-L - Headlamp control unit												V											V	V									
CLS-CLASS	218		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	218		Body	CGW - Central gateway																																	
CLS-CLASS	218		Body	AHE - Trailer recognition																																	
CLS-CLASS	218		Body	AB - Airbag																																	
CLS-CLASS	218		Information	360' - Camera																																	
CLS-CLASS	218		Information	AVE-H - Rear audio video unit																																	
CLS-CLASS	218		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLS-CLASS	218		Information	ZAN - Audio/COMAND display																																	
CLS-CLASS	218		Information	TV - TV tuner																																	
CLS-CLASS	218		Information	SOUND - Sound system																																	
CLS-CLASS	218		Information	SGR - Radar sensors control unit																																	
CLS-CLASS	218		Information	MFK - Multifunction camera																																	
CLS-CLASS	218		Information	RFK - Backup camera																																	
CLS-CLASS	218		Information	PTS - Parktronic system																																	
CLS-CLASS	218		Information	NSA - Night View Assist																																	
CLS-CLASS	218		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLS-CLASS	218		Information	NBR-RF - Right front range radar																																	
CLS-CLASS	218		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLS-CLASS	218		Information	NBR-LF - Left front range radar																																	
CLS-CLASS	218		Information	NAV - Navigation module																																	
CLS-CLASS	218		Information	MIF/UCI - Media interface																																	
CLS-CLASS	218		Information	ICI - InCar Internet																																	
CLS-CLASS	218		Information	IC - Instrument cluster							V																										
CLS-CLASS	218		Information	DVD player																																	
CLS-CLASS	218		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	218		Information	D-FOR - Display in right rear passenger																																	
CLS-CLASS	218		Information	D-FOL - Display in left rear passenger																																	
CLS-CLASS	218		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	218		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	218		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLS-CLASS	218		Information	AUDIO/COMAND																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
CLS-CLASS	218		Seat/Door	PSD/MSC - Sliding roof control																																	
CLS-CLASS	218		Seat/Door	HKS - Tailgate control																																	
CLS-CLASS	218		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	218		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	218		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	218		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	218		Seat/Door	DCM-RL - Door control module rear left																																	
CLS-CLASS	218		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	218		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	218		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	218		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	215		Drive	ME/CDI/CNG - Engine control unit																	V	V															
CL-CLASS	215		Drive	ETC - Electronic transmission control								V																									V
CL-CLASS	215		Drive	ESM - Electronic selector module																																	
CL-CLASS	215		Drive	DTR - Distronic																																	
CL-CLASS	215		Chassis	ABS/ESP - Electronic stability program																			V										V				
CL-CLASS	215		Chassis	Suspension																																	
CL-CLASS	215		Chassis	PSE - Pneumatic system equipment																																	
CL-CLASS	215		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	215		Body	UCP - Upper control panel																																	
CL-CLASS	215		Body	System diagnosis																																	
CL-CLASS	215		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	215		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	215		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CL-CLASS	215		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	215		Body	RCM - Rear control module																																	
CL-CLASS	215		Body	OCP - Overhead control panel																																	
CL-CLASS	215		Body	Multifunction control unit																																	
CL-CLASS	215		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	215		Body	HSW/LRH - Steering wheel heater																																	
CL-CLASS	215		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	215		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	215		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	215		Body	CGW - Central gateway																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
CL-CLASS	215		Body	AHE - Trailer recognition																																	
CL-CLASS	215		Body	AB - Airbag																																	
CL-CLASS	215		Information	TV - TV tuner																																	
CL-CLASS	215		Information	PTS - Parktronic system																																	
CL-CLASS	215		Information	NAV - Navigation module																																	
CL-CLASS	215		Information	IC - Instrument cluster																																	
CL-CLASS	215		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	215		Information	AUDIO/COMAND																																	
CL-CLASS	215		Information	AGW - Audio gateway																																	
CL-CLASS	215		Seat/Door	OSB-FR - Multicontour backrest front right																																	
CL-CLASS	215		Seat/Door	OSB-FL - Multicontour backrest front left																																	
CL-CLASS	215		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	215		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	215		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	215		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	215		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	215		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
CL-CLASS	215		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	216		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V					V			
CL-CLASS	216		Drive	ETC - Electronic transmission control								V																										V
CL-CLASS	216		Drive	ISM - Intelligent servo module																																	
CL-CLASS	216		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	216		Drive	DTR - Distronic																																	
CL-CLASS	216		Chassis	ABS/ESP - Electronic stability program																													V				
CL-CLASS	216		Chassis	Suspension																																	
CL-CLASS	216		Chassis	ES - Electrical power steering																																	
CL-CLASS	216		Chassis	EFB - Electric parking brake																																	
CL-CLASS	216		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	216		Body	WSS - Weight sensing system																																	
CL-CLASS	216		Body	UCP - Upper control panel																																	
CL-CLASS	216		Body	System diagnosis																																	
CL-CLASS	216		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	216		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	216		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	216		Body	RCM - Rear control module																																	
CL-CLASS	216		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
CL-CLASS	216		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	216		Body	Headlamp-R - Headlamp control unit													V																				
CL-CLASS	216		Body	Headlamp/Headlamp-L - Headlamp control unit												V												V	V								
CL-CLASS	216		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	216		Body	CGW - Central gateway																																	
CL-CLASS	216		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	216		Body	AHE - Trailer recognition																																	
CL-CLASS	216		Body	AB - Airbag																																	
CL-CLASS	216		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	216		Information	VCS - Voice control																																	
CL-CLASS	216		Information	TV - TV tuner																																	
CL-CLASS	216		Information	Tuner - Standard tuner																																	
CL-CLASS	216		Information	SGR - Radar sensors control unit																																	
CL-CLASS	216		Information	MFK - Multifunction camera																																	
CL-CLASS	216		Information	RFK - Backup camera																																	
CL-CLASS	216		Information	PTS - Parktronic system																																	
CL-CLASS	216		Information	NSA - Night View Assist																																	
CL-CLASS	216		Information	NBR-LF - Left front range radar																																	
CL-CLASS	216		Information	NAV - Navigation module																																	
CL-CLASS	216		Information	MIF/UCI - Media interface																																	
CL-CLASS	216		Information	ICI - InCar Internet																																	
CL-CLASS	216		Information	IC - Instrument cluster																																	
CL-CLASS	216		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	216		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	216		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	216		Information	AUDIO/COMAND																																	
CL-CLASS	216		Information	ASSYST PLUS - PLUS Active Service System																																	
CL-CLASS	216		Information	ASSYST Active Service System																																	
CL-CLASS	216		Seat/Door	TLC/GTO - Garage door opener																																	
CL-CLASS	216		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	216		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	216		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	216		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	216		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
CL-CLASS	216		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	216		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	216		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	217		Drive	SCR - Selective catalytic reduction	V																																
CL-CLASS	217		Drive	SG-EM - Power electronics																																	
CL-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	217		Drive	DTR - Distronic																																	
CL-CLASS	217		Drive	ISM - Intelligent servo module																																	
CL-CLASS	217		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V				V			
CL-CLASS	217		Drive	ETC - Electronic transmission control																				V													
CL-CLASS	217		Drive	PTCU - Common powertrain controller																																	
CL-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	217		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	217		Chassis	ES - Electrical power steering																																	
CL-CLASS	217		Chassis	Suspension																																	
CL-CLASS	217		Chassis	EFB - Electric parking brake																												V					
CL-CLASS	217		Information	TPAD - Touchpad																																	
CL-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	217		Information	360' - Camera																																	
CL-CLASS	217		Information	SOUND - Sound system																																	
CL-CLASS	217		Information	RFK - Backup camera																																	
CL-CLASS	217		Information	SGR - Radar sensors control unit																V																	
CL-CLASS	217		Information	PTS - Parktronic system																																	
CL-CLASS	217		Information	NSA - Night View Assist																																	
CL-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CL-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CL-CLASS	217		Information	NBR-RF - Right front range radar																																	
CL-CLASS	217		Information	NBR-LF - Left front range radar																																	
CL-CLASS	217		Information	MFK - Multifunction camera																																	
CL-CLASS	217		Information	Head-up display																																	
CL-CLASS	217		Information	AUDIO/COMAND																																	
CL-CLASS	217		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	217		Information	KAB - Camera cover																																	
CL-CLASS	217		Information	IC - Instrument cluster																																	
CL-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
CL-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CL-CLASS	217		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																											V						
CL-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	AB - Airbag																																	
CL-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	217		Body	Headlamp-R - Headlamp control unit														V																			
CL-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit			V	V							V																						
CL-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
CL-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	217		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	217		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
CL-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
CL-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	170		Drive	ME/CDI/CNG - Engine control unit																	V	V															
SLK-CLASS	170		Drive	ETC - Electronic transmission control								V																									V
SLK-CLASS	170		Drive	ESM - Electronic selector module																																	
SLK-CLASS	170		Chassis	ABS/ESP - Electronic stability program																													V				
SLK-CLASS	170		Chassis	VP - Vacuum pump brake booster																																	
SLK-CLASS	170		Chassis	BAS - Brake assist																																	
SLK-CLASS	170		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	170		Body	AB - Airbag																																	
SLK-CLASS	170		Information	IC - Instrument cluster																																	
SLK-CLASS	170		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	170		Information	AUDIO/COMAND																																	
SLK-CLASS	170		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
SLK-CLASS	170		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	171		Drive	ME/CDI/CNG - Engine control unit								V									V	V					V										
SLK-CLASS	171		Drive	ETC - Electronic transmission control								V																									V
SLK-CLASS	171		Drive	ESM - Electronic selector module																																	
SLK-CLASS	171		Chassis	ABS/ESP - Electronic stability program																													V				
SLK-CLASS	171		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	171		Body	WSS - Weight sensing system																																	
SLK-CLASS	171		Body	UCP - Upper control panel																																	
SLK-CLASS	171		Body	System diagnosis																																	
SLK-CLASS	171		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	171		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	171		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLK-CLASS	171		Body	OCP - Overhead control panel																																	
SLK-CLASS	171		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	171		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	171		Body	CGW - Central gateway																																	
SLK-CLASS	171		Body	AB - Airbag																																	
SLK-CLASS	171		Information	TV - TV tuner																																	
SLK-CLASS	171		Information	SOUND - Sound system																																	
SLK-CLASS	171		Information	PTS - Parktronic system																																	
SLK-CLASS	171		Information	MIF/UCI - Media interface																																	
SLK-CLASS	171		Information	IC - Instrument cluster																																	
SLK-CLASS	171		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	171		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	171		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SLK-CLASS	171		Information	AUDIO/COMAND																																	
SLK-CLASS	171		Information	ASSYST PLUS - PLUS Active Service System																																	
SLK-CLASS	171		Information	ASSYST Active Service System																																	
SLK-CLASS	171		Information	AGW - Audio gateway																																	
SLK-CLASS	171		Seat/Door	RVC/VDS - Convertible roof control																																	
SLK-CLASS	171		Seat/Door	HS - Seat heater																																	
SLK-CLASS	171		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	171		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	171		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	171		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	171		Air Conditioning	AAC - Automatic air conditioning																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
SLK-CLASS	172		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V					V		
SLK-CLASS	172		Drive	ETC - Electronic transmission control								V																									V
SLK-CLASS	172		Drive	ESM - Electronic selector module																																	
SLK-CLASS	172		Drive	DTR - Distronic																																	
SLK-CLASS	172		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLK-CLASS	172		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	172		Chassis	Suspension																																	
SLK-CLASS	172		Chassis	ES - Electrical power steering																																	
SLK-CLASS	172		Chassis	EFB - Electric parking brake																												V					
SLK-CLASS	172		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	172		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	172		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	172		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
SLK-CLASS	172		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	172		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLK-CLASS	172		Body	Headlamp/Headlamp-L - Headlamp control unit												V												V	V								
SLK-CLASS	172		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	172		Body	CGW - Central gateway																																	
SLK-CLASS	172		Body	AB - Airbag																																	
SLK-CLASS	172		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SLK-CLASS	172		Information	ZAN - Audio/COMAND display																																	
SLK-CLASS	172		Information	TV - TV tuner																																	
SLK-CLASS	172		Information	SOUND - Sound system																																	
SLK-CLASS	172		Information	SGR - Radar sensors control unit																																	
SLK-CLASS	172		Information	MFK - Multifunction camera																																	
SLK-CLASS	172		Information	PTS - Parktronic system																																	
SLK-CLASS	172		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLK-CLASS	172		Information	NBR-RF - Right front range radar																																	
SLK-CLASS	172		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLK-CLASS	172		Information	NBR-LF - Left front range radar																																	
SLK-CLASS	172		Information	NAV - Navigation module																																	
SLK-CLASS	172		Information	MIF/UCI - Media interface																																	
SLK-CLASS	172		Information	IC - Instrument cluster							V																										
SLK-CLASS	172		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
SLK-CLASS	172		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	172		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLK-CLASS	172		Information	AUDIO/COMAND																																	
SLK-CLASS	172		Seat/Door	RVC/VDS - Convertible roof control																																	
SLK-CLASS	172		Seat/Door	PSD/MSC - Sliding roof control																																	
SLK-CLASS	172		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	172		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	172		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	172		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	172		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	129		Drive	ME/CDI/CNG - Engine control unit																																	
SL-CLASS	129		Drive	ETC - Electronic transmission control																																	
SL-CLASS	129		Chassis	ABS/ESP - Electronic stability program																			V										V				
SL-CLASS	129		Chassis	BAS - Brake assist																																	
SL-CLASS	129		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	129		Body	AB - Airbag																																	
SL-CLASS	129		Information	NAV - Navigation module																																	
SL-CLASS	129		Information	IC - Instrument cluster																																	
SL-CLASS	129		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	129		Information	AUDIO/COMAND																																	
SL-CLASS	129		Information	APS - Auto pilot system																																	
SL-CLASS	129		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	129		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	230		Drive	ME/CDI/CNG - Engine control unit								V									V	V					V										
SL-CLASS	230		Drive	ETC - Electronic transmission control								V																									V
SL-CLASS	230		Drive	ESM - Electronic selector module																																	
SL-CLASS	230		Drive	DTR - Distronic																																	
SL-CLASS	230		Drive	AMG DRIVE UNIT																																	
SL-CLASS	230		Chassis	ABS/ESP - Electronic stability program																													V				
SL-CLASS	230		Chassis	Suspension																																	
SL-CLASS	230		Chassis	SBC - Sensotronic Brake Control																														V			
SL-CLASS	230		Chassis	PSE - Pneumatic system equipment																																	
SL-CLASS	230		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	230		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	230		Body	WSS - Weight sensing system																																	
SL-CLASS	230		Body	System diagnosis																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
SL-CLASS	230		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	230		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	230		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SL-CLASS	230		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	230		Body	OCP - Overhead control panel																																	
SL-CLASS	230		Body	LCP/HBF - Lower/Rear control panel																																	
SL-CLASS	230		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	230		Body	HSW/LRH - Steering wheel heater																																	
SL-CLASS	230		Body	Headlamp-R - Headlamp control unit																																	
SL-CLASS	230		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	230		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	230		Body	CGW - Central gateway																																	
SL-CLASS	230		Body	BNS/BMS - Battery sensor																																	
SL-CLASS	230		Body	AB - Airbag																																	
SL-CLASS	230		Information	TV - TV tuner																																	
SL-CLASS	230		Information	SOUND - Sound system																																	
SL-CLASS	230		Information	PTS - Parktronic system																																	
SL-CLASS	230		Information	MIF/UCI - Media interface																																	
SL-CLASS	230		Information	IC - Instrument cluster																																	
SL-CLASS	230		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	230		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	230		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SL-CLASS	230		Information	AUDIO/COMAND																																	
SL-CLASS	230		Information	AGW - Audio gateway																																	
SL-CLASS	230		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	230		Seat/Door	OSB-FR - Multicontour backrest front right																																	
SL-CLASS	230		Seat/Door	OSB-FL - Multicontour backrest front left																																	
SL-CLASS	230		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	230		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	230		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	230		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	230		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	230		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	231		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V					V			
SL-CLASS	231		Drive	ETC - Electronic transmission control																				V													
SL-CLASS	231		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
SL-CLASS	231		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SL-CLASS	231		Drive	DTR - Distronic																																	
SL-CLASS	231		Drive	DSI - Direct select interface																																	
SL-CLASS	231		Drive	AMG DRIVE UNIT																																	
SL-CLASS	231		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	231		Chassis	Suspension																																	
SL-CLASS	231		Chassis	ES - Electrical power steering																						V											
SL-CLASS	231		Chassis	EFB - Electric parking brake																												V					
SL-CLASS	231		Chassis	FWGW - Chassis gateway																																	
SL-CLASS	231		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	231		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	231		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	231		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
SL-CLASS	231		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	231		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	231		Body	Headlamp/Headlamp-L - Headlamp control unit												V												V	V								
SL-CLASS	231		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	231		Body	CGW - Central gateway																																	
SL-CLASS	231		Body	AB - Airbag																																	
SL-CLASS	231		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SL-CLASS	231		Information	ZAN - Audio/COMAND display																																	
SL-CLASS	231		Information	TV - TV tuner																																	
SL-CLASS	231		Information	SOUND - Sound system																																	
SL-CLASS	231		Information	SGR - Radar sensors control unit																																	
SL-CLASS	231		Information	RFK - Backup camera																																	
SL-CLASS	231		Information	MFK - Multifunction camera																																	
SL-CLASS	231		Information	PTS - Parktronic system																																	
SL-CLASS	231		Information	NSA - Night View Assist																																	
SL-CLASS	231		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SL-CLASS	231		Information	NBR-RF - Right front range radar																																	
SL-CLASS	231		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SL-CLASS	231		Information	NBR-LF - Left front range radar																																	
SL-CLASS	231		Information	MIF/UCI - Media interface																																	
SL-CLASS	231		Information	IC - Instrument cluster							V																										

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
SL-CLASS	231		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	231		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	231		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SL-CLASS	231		Information	AUDIO/COMAND																																	
SL-CLASS	231		Information	AMG Performance Media																																	
SL-CLASS	231		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	231		Seat/Door	PSD/MSC - Sliding roof control																																	
SL-CLASS	231		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	231		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	231		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
SL-CLASS	231		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	231		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	231		Air Conditioning	AAC - Automatic air conditioning																																	
SLS-CLASS	197		Drive	PTCU - Common powertrain controller																																	
SLS-CLASS	197		Drive	ME/CDI/CNG - Engine control unit								V									V	V				V											
SLS-CLASS	197		Drive	ETC - Electronic transmission control																			V														
SLS-CLASS	197		Drive	ISM - Intelligent servo module																																	
SLS-CLASS	197		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLS-CLASS	197		Drive	DSI - Direct select interface																																	
SLS-CLASS	197		Drive	AMG DRIVE UNIT																																	
SLS-CLASS	197		Chassis	ABS/ESP - Electronic stability program																																	
SLS-CLASS	197		Chassis	Suspension																																	
SLS-CLASS	197		Chassis	ES - Electrical power steering																																	
SLS-CLASS	197		Chassis	EFB - Electric parking brake																												V					
SLS-CLASS	197		Chassis	TPM - Tire pressure monitor																																	
SLS-CLASS	197		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	CSHV - Crash sensor/high-voltage battery																																	
SLS-CLASS	197		Body	BNS/BMS - Battery sensor	V								V					V						V					V					V			
SLS-CLASS	197		Body	WSS - Weight sensing system																																	
SLS-CLASS	197		Body	SCM [MRM] - Steering column module																																	
SLS-CLASS	197		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLS-CLASS	197		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
SLS-CLASS	197		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
SLS-CLASS	197		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLS-CLASS	197		Body	EZS/EIS - Electronic ignition lock																																	
SLS-CLASS	197		Body	CGW - Central gateway																																	
SLS-CLASS	197		Body	AB - Airbag																																	
SLS-CLASS	197		Information	MFK - Multifunction camera																																	
SLS-CLASS	197		Information	SGR - Radar sensors control unit																																	
SLS-CLASS	197		Information	ZAN - Audio/COMAND display																																	
SLS-CLASS	197		Information	SOUND - Sound system																																	
SLS-CLASS	197		Information	PTS - Parktronic system																																	
SLS-CLASS	197		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLS-CLASS	197		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLS-CLASS	197		Information	MIF/UCI - Media interface																																	
SLS-CLASS	197		Information	IC - Instrument cluster							V																										
SLS-CLASS	197		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLS-CLASS	197		Information	DAB/SDAR - Digital/Satellite radio																																	
SLS-CLASS	197		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLS-CLASS	197		Information	AUDIO/COMAND																																	
SLS-CLASS	197		Information	AMG Performance Media																																	
SLS-CLASS	197		Seat/Door	RVC/VDS - Convertible roof control																																	
SLS-CLASS	197		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLS-CLASS	197		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLS-CLASS	197		Seat/Door	DCM-FR - Door control module front right																																	
SLS-CLASS	197		Seat/Door	DCM-FL - Door control module front left																																	
SLS-CLASS	197		Air Conditioning	AAC - Automatic air conditioning																																	
AMG GT	190		Drive	DTR - Distronic																																	
AMG GT	190		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
AMG GT	190		Drive	DSI - Direct select interface																																	
AMG GT	190		Drive	AMG DRIVE UNIT																																	
AMG GT	190		Drive	PTCU - Common powertrain controller																																	
AMG GT	190		Drive	ME/CDI/CNG - Engine control unit										V					V						V					V					V			
AMG GT	190		Drive	ETC - Electronic transmission control																				V													
AMG GT	190		Chassis	TPM - Tire pressure monitor																																	
AMG GT	190		Chassis	Suspension																																	
AMG GT	190		Chassis	ABS/ESP - Electronic stability program																																	
AMG GT	190		Chassis	EFB - Electric parking brake																												V					
AMG GT	190		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
AMG GT	190		Information	DAB/SDAR - Digital/Satellite radio																																	
AMG GT	190		Information	SOUND - Sound system																																	
AMG GT	190		Information	RFK - Backup camera																																	
AMG GT	190		Information	PTS - Parktronic system																																	
AMG GT	190		Information	MFK - Multifunction camera																																	
AMG GT	190		Information	IC - Instrument cluster																																	
AMG GT	190		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
AMG GT	190		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
AMG GT	190		Information	AUDIO/COMAND																																	
AMG GT	190		Information	ZAN - Audio/COMAND display																																	
AMG GT	190		Information	COU [ZBE] - Audio/COMAND operating unit																																	
AMG GT	190		Information	DTA - Mbrace or TELEAID/GPS Box																																	
AMG GT	190		Information	AMG Performance Media																																	
AMG GT	190		Body	SCM [MRM] - Steering column module																																	
AMG GT	190		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
AMG GT	190		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
AMG GT	190		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
AMG GT	190		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
AMG GT	190		Body	AB - Airbag																																	
AMG GT	190		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
AMG GT	190		Body	Headlamp-R - Headlamp control unit													V																				
AMG GT	190		Body	Headlamp/Headlamp-L - Headlamp control unit												V												V	V								
AMG GT	190		Body	SG-AWF - Collision prevention assist																																	
AMG GT	190		Body	EZS/EIS - Electronic ignition lock																																	
AMG GT	190		Body	CGW - Central gateway																																	
AMG GT	190		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
AMG GT	190		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
AMG GT	190		Seat/Door	DCM-FR - Door control module front right																																	
AMG GT	190		Seat/Door	DCM-FL - Door control module front left																																	
AMG GT	190		Air Conditioning	AAC - Automatic air conditioning																																	
SLR-CLASS	199		Drive	ME/CDI/CNG - Engine control unit																	V	V															
SLR-CLASS	199		Drive	ETC - Electronic transmission control								V																									V
SLR-CLASS	199		Drive	ESM - Electronic selector module																																	
SLR-CLASS	199		Chassis	ABS/ESP - Electronic stability program																													V				
SLR-CLASS	199		Chassis	SBC - Sensotronic Brake Control																														V			
SLR-CLASS	199		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
SLR-CLASS	199		Body	WSS - Weight sensing system																																	
SLR-CLASS	199		Body	SCM [MRM] - Steering column module																																	
SLR-CLASS	199		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLR-CLASS	199		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SLR-CLASS	199		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLR-CLASS	199		Body	OCP - Overhead control panel																																	
SLR-CLASS	199		Body	LCP/HBF - Lower/Rear control panel																																	
SLR-CLASS	199		Body	Headlamp-R - Headlamp control unit																																	
SLR-CLASS	199		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLR-CLASS	199		Body	EZS/EIS - Electronic ignition lock																																	
SLR-CLASS	199		Body	CGW - Central gateway																																	
SLR-CLASS	199		Body	BNS/BMS - Battery sensor																																	
SLR-CLASS	199		Body	AB - Airbag																																	
SLR-CLASS	199		Information	IC - Instrument cluster																																	
SLR-CLASS	199		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLR-CLASS	199		Information	AUDIO/COMAND																																	
SLR-CLASS	199		Seat/Door	DCM-FR - Door control module front right																																	
SLR-CLASS	199		Seat/Door	DCM-FL - Door control module front left																																	
SLR-CLASS	199		Air Conditioning	AAC - Automatic air conditioning																																	
MAYBACH	240		Drive	ME/CDI/CNG - Engine control unit								V									V	V					V											
MAYBACH	240		Drive	ETC - Electronic transmission control								V																									V
MAYBACH	240		Drive	ESM - Electronic selector module																																	
MAYBACH	240		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
MAYBACH	240		Drive	DTR - Distronic	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
MAYBACH	240		Chassis	ABS/ESP - Electronic stability program																												V					
MAYBACH	240		Chassis	Suspension																																	
MAYBACH	240		Chassis	SBC - Sensotronic Brake Control																													V				
MAYBACH	240		Chassis	TPM - Tire pressure monitor																																	
MAYBACH	240		Body	WSS - Weight sensing system																																	
MAYBACH	240		Body	System diagnosis																																	
MAYBACH	240		Body	SCM [MRM] - Steering column module																																	
MAYBACH	240		Body	HSW/LRH - Steering wheel heater																																	
MAYBACH	240		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
MAYBACH	240		Body	AB - Airbag																																	
MAYBACH	240		Information	TV - TV tuner																																	
MAYBACH	240		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
MAYBACH	240		Information	DTA - Mbrace or TELEAID/GPS Box																																	
MAYBACH	240		Information	AGW - Audio gateway																																	
MAYBACH	240		Seat/Door	REDC/RWT - Rear end door control module																																	
MAYBACH	240		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All_Model(BETA)	16P Connector		Drive	SG-EM - Power electronics																																	
All_Model(BETA)	16P Connector		Drive	HFPM - Haptic accelerator pedal module																																	
All_Model(BETA)	16P Connector		Drive	ME/CDI/CNG - Engine control unit								V		V					V		V	V			V		V			V				V			
All_Model(BETA)	16P Connector		Drive	ETC - Electronic transmission control								V												V													V
All_Model(BETA)	16P Connector		Drive	ESM - Electronic selector module																																	
All_Model(BETA)	16P Connector		Drive	VG - Transfer case																																	
All_Model(BETA)	16P Connector		Drive	VECU - Power monitoring control unit																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-B - Electric motor control unit B																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-A - Electric motor control unit A																																	
All_Model(BETA)	16P Connector		Drive	SCR - Selective catalytic reduction	V																																
All_Model(BETA)	16P Connector		Drive	PTCU - Common powertrain controller																																	
All_Model(BETA)	16P Connector		Drive	Natural gas control unit																																	
All_Model(BETA)	16P Connector		Drive	ISM - Intelligent servo module																																	
All_Model(BETA)	16P Connector		Drive	Hydrogen tank control unit																																	
All_Model(BETA)	16P Connector		Drive	HSG - Hybrid control unit																																	
All_Model(BETA)	16P Connector		Drive	High-temperature coolant pump control unit																																	
All_Model(BETA)	16P Connector		Drive	Fuel cell control unit																																	
All_Model(BETA)	16P Connector		Drive	FSCU-R - Control unit fuel pump																																	
All_Model(BETA)	16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
All_Model(BETA)	16P Connector		Drive	EMPI - Electronic Motor Pump Inverter																																	
All_Model(BETA)	16P Connector		Drive	Electric drive control unit																																	
All_Model(BETA)	16P Connector		Drive	DTR - Distronic																V																	
All_Model(BETA)	16P Connector		Drive	DSI - Direct select interface																																	
All_Model(BETA)	16P Connector		Drive	Compressed Natural Gas Control Module																																	
All_Model(BETA)	16P Connector		Drive	CC - Cruise control																																	
All_Model(BETA)	16P Connector		Drive	BSA - Belt-driven starter/alternator																																	
All_Model(BETA)	16P Connector		Drive	AMG DRIVE UNIT																																	
All_Model(BETA)	16P Connector		Drive	ACS - Automatic clutch system																																	
All_Model(BETA)	16P Connector		Chassis	ABS/ESP - Electronic stability program																			V										V				
All_Model(BETA)	16P Connector		Chassis	Suspension																																	
All_Model(BETA)	16P Connector		Chassis	SBC - Sensotronic Brake Control																														V			
All_Model(BETA)	16P Connector		Chassis	PSE - Pneumatic system equipment																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
All_Model(BETA)	16P Connector		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
All_Model(BETA)	16P Connector		Chassis	HAQ - Interwheel differential lock at rear axle																																	
All_Model(BETA)	16P Connector		Chassis	FWGW - Chassis gateway																																	
All_Model(BETA)	16P Connector		Chassis	ES - Electrical power steering																					V												
All_Model(BETA)	16P Connector		Chassis	EFB - Electric parking brake																											V						
All_Model(BETA)	16P Connector		Chassis	BAS - Brake assist																																	
All_Model(BETA)	16P Connector		Chassis	VP - Vacuum pump brake booster																																	
All_Model(BETA)	16P Connector		Chassis	TPM - Tire pressure monitor																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
All_Model(BETA)	16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
All_Model(BETA)	16P Connector		Body	CSHV - Crash sensor/high-voltage battery																																	
All_Model(BETA)	16P Connector		Body	WSS - Weight sensing system																																	
All_Model(BETA)	16P Connector		Body	UCP - Upper control panel																																	
All_Model(BETA)	16P Connector		Body	System diagnosis																																	
All_Model(BETA)	16P Connector		Body	SG-DDW - DC/DC converter control unit																																	
All_Model(BETA)	16P Connector		Body	SG-AWF - Collision prevention assist																																	
All_Model(BETA)	16P Connector		Body	SCM [MRM] - Steering column module																																	
All_Model(BETA)	16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
All_Model(BETA)	16P Connector		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
All_Model(BETA)	16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side		V			V	V																											
All_Model(BETA)	16P Connector		Body	RevETR-RF - Right front reversible emergency tensioning retractor																										V							
All_Model(BETA)	16P Connector		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
All_Model(BETA)	16P Connector		Body	RCM - Rear control module																																V	
All_Model(BETA)	16P Connector		Body	OCP - Overhead control panel																																	
All_Model(BETA)	16P Connector		Body	Multifunction control unit																																	
All_Model(BETA)	16P Connector		Body	LCP/HBF - Lower/Rear control panel																																	
All_Model(BETA)	16P Connector		Body	LAE [LAA] - Loading floor automatically extendable																																	
All_Model(BETA)	16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
All_Model(BETA)	16P Connector		Body	HSW/LRH - Steering wheel heater																																	
All_Model(BETA)	16P Connector		Body	Headlamp-R - Headlamp control unit													V	V																			
All_Model(BETA)	16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit			V	V							V	V											V	V									
All_Model(BETA)	16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
All_Model(BETA)	16P Connector		Body	CGW - Central gateway																																	
All_Model(BETA)	16P Connector		Body	BNS/BMS - Battery sensor																																	
All_Model(BETA)	16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
All_Model(BETA)	16P Connector		Body	AHE - Trailer recognition																																	
All_Model(BETA)	16P Connector		Body	AB - Airbag																																	
All_Model(BETA)	16P Connector		Body	AAM - All activity module																																	
All_Model(BETA)	16P Connector		Information	TPAD - Touchpad																																	
All_Model(BETA)	16P Connector		Information	Head-up display																																	
All_Model(BETA)	16P Connector		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
All_Model(BETA)	16P Connector		Information	KAB - Camera cover																																	
All_Model(BETA)	16P Connector		Information	ZAN - Audio/COMAND display																																	
All_Model(BETA)	16P Connector		Information	VCS - Voice control																																	
All_Model(BETA)	16P Connector		Information	TV - TV tuner																																	
All_Model(BETA)	16P Connector		Information	Tuner - Standard tuner																																	
All_Model(BETA)	16P Connector		Information	Sound generator for exhaust system																																	
All_Model(BETA)	16P Connector		Information	SOUND - Sound system																																	
All_Model(BETA)	16P Connector		Information	SGR - Radar sensors control unit																																	
All_Model(BETA)	16P Connector		Information	360' - Camera																																	
All_Model(BETA)	16P Connector		Information	MFK - Multifunction camera																																	
All_Model(BETA)	16P Connector		Information	RFK - Backup camera																																	
All_Model(BETA)	16P Connector		Information	PTS - Parktronic system																																	
All_Model(BETA)	16P Connector		Information	NSA - Night View Assist																																	
All_Model(BETA)	16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-RF - Right front range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LF - Left front range radar																																	
All_Model(BETA)	16P Connector		Information	NAV - Navigation module																																	
All_Model(BETA)	16P Connector		Information	MIF/UCI - Media interface																																	
All_Model(BETA)	16P Connector		Information	ICI - InCar Internet																																	
All_Model(BETA)	16P Connector		Information	IC - Instrument cluster							V																										
All_Model(BETA)	16P Connector		Information	DVD player																																	
All_Model(BETA)	16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
All_Model(BETA)	16P Connector		Information	D-FOR - Display in right rear passenger																																	
All_Model(BETA)	16P Connector		Information	D-FOL - Display in left rear passenger																																	
All_Model(BETA)	16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
All_Model(BETA)	16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
All_Model(BETA)	16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
All_Model(BETA)	16P Connector		Information	CM - Compass module																																	
All_Model(BETA)	16P Connector		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning
All Model(BETA)	16P Connector		Information	AUDIO/COMAND																																	
All Model(BETA)	16P Connector		Information	ASSYST PLUS - PLUS Active Service System																																	
All Model(BETA)	16P Connector		Information	ASSYST Active Service System																																	
All Model(BETA)	16P Connector		Information	APS - Auto pilot system																																	
All Model(BETA)	16P Connector		Information	AMG Performance Media																																	
All Model(BETA)	16P Connector		Information	AGW - Audio gateway																																	
All Model(BETA)	16P Connector		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-MR - Right center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-ML - Left center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TLC/GTO - Garage door opener																																	
All Model(BETA)	16P Connector		Seat/Door	RVC/VDS - Convertible roof control																																	
All Model(BETA)	16P Connector		Seat/Door	REDC/RWT - Rear end door control module																																	
All Model(BETA)	16P Connector		Seat/Door	PSD/MSC - Sliding roof control																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-R - Multicontour backrest rear																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FR - Multicontour backrest front right																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FL - Multicontour backrest front left																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	HS - Seat heater																																	
All Model(BETA)	16P Connector		Seat/Door	HKS - Tailgate control																																	
All Model(BETA)	16P Connector		Seat/Door	ESA-R - Electric seat adjustment rear																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
All Model(BETA)	16P Connector		Seat/Door	ERA - Electric fold down backrest system																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-RR - Door control module rear right																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-RL - Door control module rear left																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-FR - Door control module front right																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-FL - Door control module front left																																	
All Model(BETA)	16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All Model(BETA)	16P Connector		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
All Model(BETA)	16P Connector		Air Conditioning	HBF - Rear control panel																																	
All Model(BETA)	16P Connector		Air Conditioning	HB - Heater booster																																	
All Model(BETA)	16P Connector		Air Conditioning	EKMK - Electric refrigerant compressor																																	
All Model(BETA)	16P Connector		Air Conditioning	AAC - Automatic air conditioning																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
A-CLASS	68		Drive	ME/CDI/CNG - Engine control unit																																	
A-CLASS	68		Drive	ETC - Electronic transmission control																																	
A-CLASS	68		Drive	ESM - Electronic selector module																																	
A-CLASS	68		Drive	ACS - Automatic clutch system																																	
A-CLASS	68		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Body	LCP/HBF - Lower/Rear control panel																																	
A-CLASS	168		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	168		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	168		Body	AB - Airbag																																	
A-CLASS	168		Information	PTS - Parktronic system																																	
A-CLASS	168		Information	IC - Instrument cluster					V			V																									
A-CLASS	168		Information	AUDIO/COMAND																																	
A-CLASS	168		Information	APS - Auto pilot system																																	
A-CLASS	168		Seat/Door	DCM-RR - Door control module rear right																																	
A-CLASS	168		Seat/Door	DCM-RL - Door control module rear left																																	
A-CLASS	168		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	168		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	168		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	168		Air Conditioning	HB - Heater booster																																	
A-CLASS	168		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	169		Drive	ME/CDI/CNG - Engine control unit															V	V			V	V		V		V		V						V		
A-CLASS	169		Drive	ETC - Electronic transmission control																																	
A-CLASS	169		Drive	ESM - Electronic selector module																																	
A-CLASS	169		Drive	BSA - Belt-driven starter/alternator																																	
A-CLASS	169		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	169		Chassis	ES - Electrical power steering																																	
A-CLASS	169		Body	SCM [MRM] - Steering column module																																	
A-CLASS	169		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
A-CLASS	169		Body	OCP - Overhead control panel																																	
A-CLASS	169		Body	Multifunction control unit																																	
A-CLASS	169		Body	Headlamp-R - Headlamp control unit																																	
A-CLASS	169		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
A-CLASS	169		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	169		Body	CGW - Central gateway																																	
A-CLASS	169		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
A-CLASS	169		Body	AHE - Trailer recognition																																	
A-CLASS	169		Body	AB - Airbag																																	
A-CLASS	169		Information	SOUND - Sound system																																	
A-CLASS	169		Information	PTS - Parktronic system																																	
A-CLASS	169		Information	MIF/UCI - Media interface																																	
A-CLASS	169		Information	IC - Instrument cluster																																	
A-CLASS	169		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	169		Information	CTEL/TEL - Cellular/Mobile telephone																																	
A-CLASS	169		Information	AUDIO/COMAND																																	
A-CLASS	169		Information	ASSYST PLUS - PLUS Active Service System																																	
A-CLASS	169		Information	ASSYST Active Service System																																	
A-CLASS	169		Information	AGW - Audio gateway																																	
A-CLASS	169		Seat/Door	DCM-RR - Door control module rear right																																	
A-CLASS	169		Seat/Door	DCM-RL - Door control module rear left																																	
A-CLASS	169		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	169		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	169		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	176		Drive	VG - Transfer case																																	
A-CLASS	176		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
A-CLASS	176		Drive	ETC - Electronic transmission control												V																	V				
A-CLASS	176		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
A-CLASS	176		Drive	DTR - Distronic																																	
A-CLASS	176		Drive	DSI - Direct select interface																																	
A-CLASS	176		Drive	PTCU - Common powertrain controller																																	
A-CLASS	176		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	176		Chassis	ES - Electrical power steering																																	
A-CLASS	176		Chassis	EFB - Electric parking brake																																	
A-CLASS	176		Chassis	TPM - Tire pressure monitor																																	
A-CLASS	176		Body	SG-AWF - Collision prevention assist																																	
A-CLASS	176		Body	SCM [MRM] - Steering column module																																	
A-CLASS	176		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
A-CLASS	176		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	Multifunction control unit																																	
A-CLASS	176		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	176		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
A-CLASS	176		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	176		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	176		Body	AHE - Trailer recognition																																	
A-CLASS	176		Body	AB - Airbag																																	
A-CLASS	176		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
A-CLASS	176		Information	ZAN - Audio/COMAND display																																	
A-CLASS	176		Information	TV - TV tuner																																	
A-CLASS	176		Information	SOUND - Sound system																																	
A-CLASS	176		Information	RFK - Backup camera																																	
A-CLASS	176		Information	MFK - Multifunction camera																																	
A-CLASS	176		Information	PTS - Parktronic system																																	
A-CLASS	176		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
A-CLASS	176		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
A-CLASS	176		Information	NAV - Navigation module																																	
A-CLASS	176		Information	MIF/UCI - Media interface																																	
A-CLASS	176		Information	IC - Instrument cluster			V																														
A-CLASS	176		Information	DTA - Mbrace or TELEAID/GPS Box																																	
A-CLASS	176		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	176		Information	COU [ZBE] - Audio/COMAND operating unit																																	
A-CLASS	176		Information	AUDIO/COMAND	V																																
A-CLASS	176		Seat/Door	PSD/MSC - Sliding roof control																																	
A-CLASS	176		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
A-CLASS	176		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
A-CLASS	176		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	176		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	176		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	176		Air Conditioning	AAC - Automatic air conditioning														V								V											
B-CLASS	245		Drive	ME/CDI/CNG - Engine control unit																				V													
B-CLASS	245		Drive	ETC - Electronic transmission control																																	
B-CLASS	245		Drive	ESM - Electronic selector module																																	
B-CLASS	245		Drive	Hydrogen tank control unit																																	
B-CLASS	245		Drive	High-temperature coolant pump control unit																																	
B-CLASS	245		Drive	Fuel cell control unit																																	
B-CLASS	245		Drive	Electric drive control unit																																	
B-CLASS	245		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	245		Drive	BSA - Belt-driven starter/alternator																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
B-CLASS	245		Drive	VECU - Power monitoring control unit																																	
B-CLASS	245		Chassis	ABS/ESP - Electronic stability program																																	
B-CLASS	245		Chassis	ES - Electrical power steering																																	
B-CLASS	245		Chassis	VP - Vacuum pump brake booster																																	
B-CLASS	245		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	245		Body	WSS - Weight sensing system																																	
B-CLASS	245		Body	SG-DDW - DC/DC converter control unit																																	
B-CLASS	245		Body	SCM [MRM] - Steering column module																																	
B-CLASS	245		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
B-CLASS	245		Body	OCP - Overhead control panel																																	
B-CLASS	245		Body	Multifunction control unit																																	
B-CLASS	245		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	245		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	245		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	245		Body	CGW - Central gateway																																	
B-CLASS	245		Body	BNS/BMS - Battery sensor																																	
B-CLASS	245		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	245		Body	AHE - Trailer recognition																																	
B-CLASS	245		Body	AB - Airbag																																	
B-CLASS	245		Information	SOUND - Sound system																																	
B-CLASS	245		Information	PTS - Parktronic system																																	
B-CLASS	245		Information	NAV - Navigation module																																	
B-CLASS	245		Information	MIF/UCI - Media interface																																	
B-CLASS	245		Information	IC - Instrument cluster																																	
B-CLASS	245		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	245		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	245		Information	CTEL/TEL - Cellular/Mobile telephone																																	
B-CLASS	245		Information	CM - Compass module																																	
B-CLASS	245		Information	AUDIO/COMAND																																	
B-CLASS	245		Information	ASSYST PLUS - PLUS Active Service System																																	
B-CLASS	245		Information	ASSYST Active Service System																																	
B-CLASS	245		Information	AGW - Audio gateway																																	
B-CLASS	245		Seat/Door	DCM-RR - Door control module rear right																																	
B-CLASS	245		Seat/Door	DCM-RL - Door control module rear left																																	
B-CLASS	245		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	245		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
B-CLASS	245		Air Conditioning	EKMK - Electric refrigerant compressor																																	
B-CLASS	245		Air Conditioning	AAC - Automatic air conditioning																																	
B-CLASS	246		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	246		Drive	VG - Transfer case																																	
B-CLASS	246		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
B-CLASS	246		Drive	ETC - Electronic transmission control												V																	V			
B-CLASS	246		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
B-CLASS	246		Drive	DTR - Distronic																																	
B-CLASS	246		Drive	PTCU - Common powertrain controller																																	
B-CLASS	246		Chassis	ABS/ESP - Electronic stability program																																	
B-CLASS	246		Chassis	ES - Electrical power steering																																	
B-CLASS	246		Chassis	EFB - Electric parking brake																																	
B-CLASS	246		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	246		Body	BNS/BMS - Battery sensor																																	
B-CLASS	246		Body	SG-AWF - Collision prevention assist																																	
B-CLASS	246		Body	SCM [MRM] - Steering column module																																	
B-CLASS	246		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
B-CLASS	246		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	Multifunction control unit																																	
B-CLASS	246		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
B-CLASS	246		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	246		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	246		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	246		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	246		Body	AHE - Trailer recognition																																	
B-CLASS	246		Body	AB - Airbag																																	
B-CLASS	246		Information	Sound generator for exhaust system																																	
B-CLASS	246		Information	Head-up display																																	
B-CLASS	246		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
B-CLASS	246		Information	ZAN - Audio/COMAND display																																	
B-CLASS	246		Information	TV - TV tuner																																	
B-CLASS	246		Information	SOUND - Sound system																																	
B-CLASS	246		Information	RFK - Backup camera																																	
B-CLASS	246		Information	MFK - Multifunction camera																																	
B-CLASS	246		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
B-CLASS	246		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
B-CLASS	246		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
B-CLASS	246		Information	NAV - Navigation module																																	
B-CLASS	246		Information	MIF/UCI - Media interface																																	
B-CLASS	246		Information	IC - Instrument cluster			V																														
B-CLASS	246		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	246		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	246		Information	COU [ZBE] - Audio/COMAND operating unit																																	
B-CLASS	246		Information	AUDIO/COMAND	V																																
B-CLASS	246		Seat/Door	PSD/MSC - Sliding roof control																																	
B-CLASS	246		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
B-CLASS	246		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
B-CLASS	246		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	246		Seat/Door	DCM-FL - Door control module front left																																	
B-CLASS	246		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
B-CLASS	246		Air Conditioning	AAC - Automatic air conditioning													V									V											
C-CLASS	202		Drive	ME/CDI/CNG - Engine control unit		V																															
C-CLASS	202		Drive	ETC - Electronic transmission control																																	
C-CLASS	202		Drive	ESM - Electronic selector module																																	
C-CLASS	202		Chassis	PSE - Pneumatic system equipment																																	
C-CLASS	202		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	202		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	202		Chassis	BAS - Brake assist																																	
C-CLASS	202		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	202		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	202		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	202		Body	OCP - Overhead control panel																																	
C-CLASS	202		Body	AB - Airbag																																	
C-CLASS	202		Information	PTS - Parktronic system																																	
C-CLASS	202		Information	NAV - Navigation module																																	
C-CLASS	202		Information	IC - Instrument cluster					V			V																									
C-CLASS	202		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	202		Information	AUDIO/COMAND																																	
C-CLASS	202		Information	APS - Auto pilot system																																	
C-CLASS	202		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	202		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
C-CLASS	202		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	202		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	202		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	202		Air Conditioning	HB - Heater booster																																	
C-CLASS	202		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	203		Drive	ME/CDI/CNG - Engine control unit		V																		V													
C-CLASS	203		Drive	ETC - Electronic transmission control																																	
C-CLASS	203		Drive	ESM - Electronic selector module																																	
C-CLASS	203		Drive	DTR - Distronic																																	
C-CLASS	203		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	203		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	203		Chassis	BAS - Brake assist																																	
C-CLASS	203		Body	WSS - Weight sensing system																																	
C-CLASS	203		Body	UCP - Upper control panel																																	
C-CLASS	203		Body	System diagnosis																																	
C-CLASS	203		Body	SCM [MRM] - Steering column module																																	
C-CLASS	203		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	203		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	203		Body	OCP - Overhead control panel																																	
C-CLASS	203		Body	Multifunction control unit																																	
C-CLASS	203		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	203		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	203		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	203		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	203		Body	CGW - Central gateway																																	
C-CLASS	203		Body	AHE - Trailer recognition																																	
C-CLASS	203		Body	AB - Airbag																																	
C-CLASS	203		Information	TV - TV tuner																																	
C-CLASS	203		Information	SOUND - Sound system																																	
C-CLASS	203		Information	PTS - Parktronic system																																	
C-CLASS	203		Information	NAV - Navigation module																																	
C-CLASS	203		Information	MIF/UCI - Media interface																																	
C-CLASS	203		Information	IC - Instrument cluster																																	
C-CLASS	203		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	203		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	203		Information	CTEL/TEL - Cellular/Mobile telephone																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
C-CLASS	203		Information	AUDIO/COMAND																																	
C-CLASS	203		Information	AGW - Audio gateway																																	
C-CLASS	203		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	203		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	203		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	203		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	203		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	203		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	203		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	203		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	204		Drive	ME/CDI/CNG - Engine control unit															V	V			V	V		V		V		V						V		
C-CLASS	204		Drive	ETC - Electronic transmission control												V																		V			
C-CLASS	204		Drive	ESM - Electronic selector module																																	
C-CLASS	204		Drive	SCR - Selective catalytic reduction																																	
C-CLASS	204		Drive	ISM - Intelligent servo module																																	
C-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
C-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	204		Drive	DTR - Distronic																																	
C-CLASS	204		Drive	AMG DRIVE UNIT																																	
C-CLASS	204		Drive	PTCU - Common powertrain controller																																	
C-CLASS	204		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	204		Chassis	Suspension																																	
C-CLASS	204		Chassis	ES - Electrical power steering																																	
C-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	204		Body	WSS - Weight sensing system																																	
C-CLASS	204		Body	SCM [MRM] - Steering column module																																	
C-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	OCP - Overhead control panel																																	
C-CLASS	204		Body	Multifunction control unit																																	
C-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	204		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
C-CLASS	204		Body	CGW - Central gateway																																	
C-CLASS	204		Body	AHE - Trailer recognition																																	
C-CLASS	204		Body	AB - Airbag																																	
C-CLASS	204		Information	Head-up display																																	
C-CLASS	204		Information	AVE-H - Rear audio video unit																																	
C-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
C-CLASS	204		Information	ZAN - Audio/COMAND display																																	
C-CLASS	204		Information	TV - TV tuner																																	
C-CLASS	204		Information	Sound generator for exhaust system																																	
C-CLASS	204		Information	SOUND - Sound system																																	
C-CLASS	204		Information	SGR - Radar sensors control unit																																	
C-CLASS	204		Information	360' - Camera																																	
C-CLASS	204		Information	MFK - Multifunction camera																																	
C-CLASS	204		Information	RFK - Backup camera											V																						
C-CLASS	204		Information	PTS - Parktronic system																																	
C-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	204		Information	NBR-RF - Right front range radar																																	
C-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	204		Information	NBR-LF - Left front range radar																																	
C-CLASS	204		Information	NAV - Navigation module																																	
C-CLASS	204		Information	MIF/UCI - Media interface																																	
C-CLASS	204		Information	ICI - InCar Internet																																	
C-CLASS	204		Information	IC - Instrument cluster			V																														
C-CLASS	204		Information	DVD player																																	
C-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
C-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
C-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
C-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	204		Information	AUDIO/COMAND	V																																
C-CLASS	204		Information	AMG Performance Media																																	
C-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	204		Seat/Door	HKS - Tailgate control																											V	V				V	
C-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
C-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	204		Air Conditioning	AAC - Automatic air conditioning														V								V											
C-CLASS	205		Drive	SCR - Selective catalytic reduction																																	
C-CLASS	205		Drive	SG-EM - Power electronics																																	
C-CLASS	205		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	205		Drive	HFPM - Haptic accelerator pedal module																																	
C-CLASS	205		Drive	DTR - Distronic																																	
C-CLASS	205		Drive	ISM - Intelligent servo module																																	
C-CLASS	205		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
C-CLASS	205		Drive	ETC - Electronic transmission control												V																	V			
C-CLASS	205		Drive	PTCU - Common powertrain controller																																	
C-CLASS	205		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	205		Chassis	Suspension																																	
C-CLASS	205		Chassis	ABS/ESP - Electronic stability program																	V	V			V												
C-CLASS	205		Chassis	ES - Electrical power steering																																	
C-CLASS	205		Chassis	EFB - Electric parking brake																																	
C-CLASS	205		Information	TPAD - Touchpad																																	
C-CLASS	205		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	205		Information	360' - Camera																																	
C-CLASS	205		Information	Sound generator for exhaust system																																	
C-CLASS	205		Information	SOUND - Sound system																																	
C-CLASS	205		Information	RFK - Backup camera																																	
C-CLASS	205		Information	SGR - Radar sensors control unit																																	
C-CLASS	205		Information	PTS - Parktronic system																																	
C-CLASS	205		Information	NBR-RF - Right front range radar																																	
C-CLASS	205		Information	NBR-LF - Left front range radar																																	
C-CLASS	205		Information	MFK - Multifunction camera																																	
C-CLASS	205		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	205		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	205		Information	Head-up display																																	
C-CLASS	205		Information	AUDIO/COMAND																																	
C-CLASS	205		Information	ZAN - Audio/COMAND display																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
C-CLASS	205		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	205		Information	KAB - Camera cover																																	
C-CLASS	205		Information	IC - Instrument cluster			V																														
C-CLASS	205		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	205		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
C-CLASS	205		Body	AHE - Trailer recognition																																	
C-CLASS	205		Body	SCM [MRM] - Steering column module																																	
C-CLASS	205		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	AB - Airbag																																	
C-CLASS	205		Body	Multifunction control unit																																	
C-CLASS	205		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	205		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	205		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	205		Body	SG-AWF - Collision prevention assist																																	
C-CLASS	205		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	205		Body	BNS/BMS - Battery sensor																																	
C-CLASS	205		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	205		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	205		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	205		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	205		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	205		Seat/Door	HKS - Tailgate control																																	V
C-CLASS	205		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	205		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	205		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	205		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	205		Seat/Door	RVC/VDS - Convertible roof control																																	
C-CLASS	205		Air Conditioning	AAC - Automatic air conditioning																							V										
E-CLASS	124		Drive	PMS/HFM/LH																																	
E-CLASS	124		Drive	ETC - Electronic transmission control																																	
E-CLASS	124		Drive	ISC - Idle speed control																																	
E-CLASS	124		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	124		Body	AB - Airbag																																	
E-CLASS	210		Drive	ME/CDI/CNG - Engine control unit		V																															
E-CLASS	210		Drive	ETC - Electronic transmission control																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
E-CLASS	210		Drive	ESM - Electronic selector module																																	
E-CLASS	210		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	210		Chassis	VP - Vacuum pump brake booster																																	
E-CLASS	210		Chassis	PSE - Pneumatic system equipment																																	
E-CLASS	210		Chassis	BAS - Brake assist																																	
E-CLASS	210		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	210		Body	OCP - Overhead control panel																																	
E-CLASS	210		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	210		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	210		Body	AB - Airbag																																	
E-CLASS	210		Information	TV - TV tuner																																	
E-CLASS	210		Information	PTS - Parktronic system																																	
E-CLASS	210		Information	NAV - Navigation module																																	
E-CLASS	210		Information	IC - Instrument cluster					V			V																									
E-CLASS	210		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	210		Information	AUDIO/COMAND																																	
E-CLASS	210		Information	APS - Auto pilot system																																	
E-CLASS	210		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	210		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	210		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	210		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	210		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	210		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	210		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	210		Air Conditioning	HB - Heater booster																																	
E-CLASS	210		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	211		Drive	ME/CDI/CNG - Engine control unit		V																		V													
E-CLASS	211		Drive	ETC - Electronic transmission control																																	
E-CLASS	211		Drive	ESM - Electronic selector module																																	
E-CLASS	211		Drive	Natural gas control unit																																	
E-CLASS	211		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	211		Drive	DTR - Distronic																																	
E-CLASS	211		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	211		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	211		Chassis	Suspension																																	
E-CLASS	211		Chassis	SBC - Sensotronic Brake Control																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
E-CLASS	211		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	211		Body	WSS - Weight sensing system																																	
E-CLASS	211		Body	UCP - Upper control panel																																	
E-CLASS	211		Body	System diagnosis																																	
E-CLASS	211		Body	SCM [MRM] - Steering column module																																	
E-CLASS	211		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	211		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
E-CLASS	211		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	211		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	OCP - Overhead control panel																																	
E-CLASS	211		Body	Multifunction control unit																																	
E-CLASS	211		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	211		Body	LAE [LAA] - Loading floor automatically extendable																																	
E-CLASS	211		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	211		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	211		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	211		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	211		Body	CGW - Central gateway																																	
E-CLASS	211		Body	BNS/BMS - Battery sensor																																	
E-CLASS	211		Body	AHE - Trailer recognition																																	
E-CLASS	211		Body	AB - Airbag																																	
E-CLASS	211		Information	TV - TV tuner																																	
E-CLASS	211		Information	SOUND - Sound system																																	
E-CLASS	211		Information	PTS - Parktronic system																																	
E-CLASS	211		Information	MIF/UCI - Media interface																																	
E-CLASS	211		Information	IC - Instrument cluster																																	
E-CLASS	211		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	211		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	211		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	211		Information	AUDIO/COMAND																																	
E-CLASS	211		Information	ASSYST PLUS - PLUS Active Service System																																	
E-CLASS	211		Information	ASSYST Active Service System																																	
E-CLASS	211		Information	AGW - Audio gateway																																	
E-CLASS	211		Seat/Door	REDC/RWT - Rear end door control module																																	
E-CLASS	211		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
E-CLASS	211		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	211		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	211		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	211		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	211		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	211		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	211		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	211		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	211		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	207		Drive	SG-EM - Power electronics																																	
E-CLASS	207		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	207		Drive	ME/CDI/CNG - Engine control unit															V	V			V	V		V		V		V					V		
E-CLASS	207		Drive	ETC - Electronic transmission control												V																	V			
E-CLASS	207		Drive	ESM - Electronic selector module																																	
E-CLASS	207		Drive	ISM - Intelligent servo module																																	
E-CLASS	207		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	207		Drive	DTR - Distronic																																	
E-CLASS	207		Drive	DSI - Direct select interface																																	
E-CLASS	207		Drive	AMG DRIVE UNIT																																	
E-CLASS	207		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	207		Chassis	Suspension																																	
E-CLASS	207		Chassis	ES - Electrical power steering																																	
E-CLASS	207		Chassis	FWGW - Chassis gateway																																	
E-CLASS	207		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	207		Body	BNS/BMS - Battery sensor																																	
E-CLASS	207		Body	WSS - Weight sensing system																																	
E-CLASS	207		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	207		Body	SCM [MRM] - Steering column module																																	
E-CLASS	207		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	207		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	207		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	207		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	207		Body	Multifunction control unit																																	
E-CLASS	207		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
E-CLASS	207		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
E-CLASS	207		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	207		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	207		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	207		Body	CGW - Central gateway																																	
E-CLASS	207		Body	AHE - Trailer recognition																																	
E-CLASS	207		Body	AB - Airbag																																	
E-CLASS	207		Information	NBR-RF - Right front range radar																																	
E-CLASS	207		Information	NBR-LF - Left front range radar																																	
E-CLASS	207		Information	AVE-H - Rear audio video unit																																	
E-CLASS	207		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	207		Information	ZAN - Audio/COMAND display																																	
E-CLASS	207		Information	TV - TV tuner																																	
E-CLASS	207		Information	SOUND - Sound system																																	
E-CLASS	207		Information	SGR - Radar sensors control unit																																	
E-CLASS	207		Information	360' - Camera																																	
E-CLASS	207		Information	MFK - Multifunction camera																																	
E-CLASS	207		Information	RFK - Backup camera											V																						
E-CLASS	207		Information	PTS - Parktronic system																																	
E-CLASS	207		Information	NSA - Night View Assist																																	
E-CLASS	207		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	207		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	207		Information	NAV - Navigation module																																	
E-CLASS	207		Information	MIF/UCI - Media interface																																	
E-CLASS	207		Information	ICI - InCar Internet																																	
E-CLASS	207		Information	IC - Instrument cluster			V																														
E-CLASS	207		Information	DVD player																																	
E-CLASS	207		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	207		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	207		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	207		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	207		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	207		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	207		Information	AUDIO/COMAND	V																																
E-CLASS	207		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	207		Seat/Door	PSD/MSC - Sliding roof control																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
E-CLASS	207		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	207		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	207		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	207		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	207		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	207		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	207		Air Conditioning	AAC - Automatic air conditioning														V								V											
E-CLASS	212		Drive	SG-EM - Power electronics																																	
E-CLASS	212		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	212		Drive	ME/CDI/CNG - Engine control unit															V	V			V	V		V		V		V					V		
E-CLASS	212		Drive	ETC - Electronic transmission control												V																	V			
E-CLASS	212		Drive	ESM - Electronic selector module																																	
E-CLASS	212		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	212		Drive	ISM - Intelligent servo module																																	
E-CLASS	212		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	212		Drive	DTR - Distronic																																	
E-CLASS	212		Drive	DSI - Direct select interface																																	
E-CLASS	212		Drive	AMG DRIVE UNIT																																	
E-CLASS	212		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	212		Chassis	Suspension																																	
E-CLASS	212		Chassis	ES - Electrical power steering																																	
E-CLASS	212		Chassis	FWGW - Chassis gateway																																	
E-CLASS	212		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	212		Body	BNS/BMS - Battery sensor																																	
E-CLASS	212		Body	WSS - Weight sensing system																																	
E-CLASS	212		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	212		Body	SCM [MRM] - Steering column module																																	
E-CLASS	212		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	212		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	212		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	OCP - Overhead control panel																																	
E-CLASS	212		Body	Multifunction control unit																																	
E-CLASS	212		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
E-CLASS	212		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	212		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
E-CLASS	212		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	212		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	212		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	212		Body	CGW - Central gateway																																	
E-CLASS	212		Body	AHE - Trailer recognition																																	
E-CLASS	212		Body	AB - Airbag																																	
E-CLASS	212		Information	Head-up display																																	
E-CLASS	212		Information	AVE-H - Rear audio video unit																																	
E-CLASS	212		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	212		Information	ZAN - Audio/COMAND display																																	
E-CLASS	212		Information	TV - TV tuner																																	
E-CLASS	212		Information	SOUND - Sound system																																	
E-CLASS	212		Information	SGR - Radar sensors control unit																																	
E-CLASS	212		Information	360' - Camera																																	
E-CLASS	212		Information	MFK - Multifunction camera																																	
E-CLASS	212		Information	RFK - Backup camera											V																						
E-CLASS	212		Information	PTS - Parktronic system																																	
E-CLASS	212		Information	NSA - Night View Assist																																	
E-CLASS	212		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	212		Information	NBR-RF - Right front range radar																																	
E-CLASS	212		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	212		Information	NBR-LF - Left front range radar																																	
E-CLASS	212		Information	NAV - Navigation module																																	
E-CLASS	212		Information	MIF/UCI - Media interface																																	
E-CLASS	212		Information	ICI - InCar Internet																																	
E-CLASS	212		Information	IC - Instrument cluster			V																														
E-CLASS	212		Information	DVD player																																	
E-CLASS	212		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	212		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	212		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	212		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	212		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	212		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	212		Information	AUDIO/COMAND	V																																
E-CLASS	212		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	212		Seat/Door	HKS - Tailgate control																											V	V				V	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
E-CLASS	212		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	212		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	212		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	212		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	212		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	212		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	212		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	212		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	212		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	212		Air Conditioning	AAC - Automatic air conditioning														V								V											
E-CLASS	213		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	213		Drive	DTR - Distronic																																	
E-CLASS	213		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	213		Drive	HFPM - Haptic accelerator pedal module																																	
E-CLASS	213		Drive	AMG DRIVE UNIT																																	
E-CLASS	213		Drive	PTCU - Common powertrain controller																																	
E-CLASS	213		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
E-CLASS	213		Drive	ETC - Electronic transmission control												V																	V			
E-CLASS	213		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	213		Chassis	AIRMATIC PLUS																																	
E-CLASS	213		Chassis	ES - Electrical power steering																																	
E-CLASS	213		Chassis	Suspension																																	
E-CLASS	213		Chassis	ABS/ESP - Electronic stability program																	V	V			V												
E-CLASS	213		Body	MTAS - Mobile phone cradle																																	
E-CLASS	213		Body	AHE - Trailer recognition																																	
E-CLASS	213		Body	SCM [MRM] - Steering column module																																	
E-CLASS	213		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
E-CLASS	213		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
E-CLASS	213		Body	AB - Airbag																																	
E-CLASS	213		Body	OCP - Overhead control panel																																	
E-CLASS	213		Body	Multifunction control unit																																	
E-CLASS	213		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
E-CLASS	213		Body	SG-DDW - DC/DC converter control unit																																	
E-CLASS	213		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	213		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	213		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	213		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	213		Body	BNS/BMS - Battery sensor																																	
E-CLASS	213		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	213		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	213		Body	AML - Ambiance light																																	
E-CLASS	213		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	213		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	213		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
E-CLASS	213		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
E-CLASS	213		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	213		Seat/Door	HKS - Tailgate control																																	V
E-CLASS	213		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	213		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	213		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	213		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	213		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	213		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	213		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	213		Information	TPAD - Touchpad																																	
E-CLASS	213		Information	Sound generator for exhaust system																																	
E-CLASS	213		Information	SOUND - Sound system																																	
E-CLASS	213		Information	RFK - Backup camera																																	
E-CLASS	213		Information	PTS - Parktronic system																																	
E-CLASS	213		Information	MFK - Multifunction camera																																	
E-CLASS	213		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	213		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	213		Information	SGR - Radar sensors control unit																																	
E-CLASS	213		Information	IC - Instrument cluster			V																														

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
E-CLASS	213		Information	Head-up display																																	
E-CLASS	213		Information	AUDIO/COMAND																																	
E-CLASS	213		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	213		Information	ZAN - Audio/COMAND display																																	
E-CLASS	213		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	213		Air Conditioning	AAC - Automatic air conditioning																							V										
S-CLASS	140		Drive	ASF																																	
S-CLASS	140		Drive	ERE																																	
S-CLASS	140		Drive	ME1LI																																	
S-CLASS	140		Drive	ME1RE																																	
S-CLASS	140		Drive	HFM/ME2/LH																																	
S-CLASS	140		Drive	ETC - Electronic transmission control																																	
S-CLASS	140		Drive	ISC - Idle speed control																																	
S-CLASS	140		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	140		Chassis	BAS - Brake assist																																	
S-CLASS	140		Body	PSE - Pneumatic system equipment																																	
S-CLASS	140		Body	AB - Airbag																																	
S-CLASS	140		Information	PTS - Parktronic system																																	
S-CLASS	140		Information	IC - Instrument cluster				V																													
S-CLASS	140		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	220		Drive	ME/CDI/CNG - Engine control unit																				V													
S-CLASS	220		Drive	ETC - Electronic transmission control																																	
S-CLASS	220		Drive	ESM - Electronic selector module																																	
S-CLASS	220		Drive	DTR - Distronic																																	
S-CLASS	220		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	220		Chassis	Suspension																																	
S-CLASS	220		Chassis	PSE - Pneumatic system equipment																																	
S-CLASS	220		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	220		Body	UCP - Upper control panel																																	
S-CLASS	220		Body	System diagnosis																																	
S-CLASS	220		Body	SCM [MRM] - Steering column module																																	
S-CLASS	220		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	220		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
S-CLASS	220		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	220		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	220		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
S-CLASS	220		Body	OCP - Overhead control panel																																	
S-CLASS	220		Body	Multifunction control unit																																	
S-CLASS	220		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	220		Body	HSW/LRH - Steering wheel heater																																	
S-CLASS	220		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	220		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	220		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	220		Body	CGW - Central gateway																																	
S-CLASS	220		Body	AHE - Trailer recognition																																	
S-CLASS	220		Body	AB - Airbag																																	
S-CLASS	220		Information	TV - TV tuner																																	
S-CLASS	220		Information	PTS - Parktronic system																																	
S-CLASS	220		Information	NAV - Navigation module																																	
S-CLASS	220		Information	IC - Instrument cluster					V			V																									
S-CLASS	220		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	220		Information	AUDIO/COMAND																																	
S-CLASS	220		Information	AGW - Audio gateway																																	
S-CLASS	220		Seat/Door	OSB-R - Multicontour backrest rear																																	
S-CLASS	220		Seat/Door	OSB-FL - Multicontour backrest front left																																	
S-CLASS	220		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	220		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	220		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	220		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	220		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	220		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	220		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	220		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	220		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	220		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	220		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	221		Drive	ME/CDI/CNG - Engine control unit															V	V			V	V		V		V		V					V		
S-CLASS	221		Drive	ETC - Electronic transmission control																																	
S-CLASS	221		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	221		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
S-CLASS	221		Drive	HSG - Hybrid control unit																	V	V			V												
S-CLASS	221		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	221		Drive	DTR - Distronic																																	
S-CLASS	221		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	221		Chassis	Suspension																																	
S-CLASS	221		Chassis	ES - Electrical power steering																																	
S-CLASS	221		Chassis	EFB - Electric parking brake																																	
S-CLASS	221		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	221		Body	WSS - Weight sensing system																																	
S-CLASS	221		Body	UCP - Upper control panel																																	
S-CLASS	221		Body	System diagnosis																																	
S-CLASS	221		Body	SG-DDW - DC/DC converter control unit																																	
S-CLASS	221		Body	SCM [MRM] - Steering column module																																	
S-CLASS	221		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	221		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	221		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	OCP - Overhead control panel																																	
S-CLASS	221		Body	Multifunction control unit																																	
S-CLASS	221		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	221		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	221		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	221		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	221		Body	CGW - Central gateway																																	
S-CLASS	221		Body	BNS/BMS - Battery sensor																																	
S-CLASS	221		Body	AHE - Trailer recognition																																	
S-CLASS	221		Body	AB - Airbag																																	
S-CLASS	221		Information	ZAN - Audio/COMAND display																																	
S-CLASS	221		Information	VCS - Voice control																																	
S-CLASS	221		Information	TV - TV tuner																																	
S-CLASS	221		Information	Tuner - Standard tuner																																	
S-CLASS	221		Information	SOUND - Sound system																																	
S-CLASS	221		Information	SGR - Radar sensors control unit																																	
S-CLASS	221		Information	MFK - Multifunction camera																																	
S-CLASS	221		Information	RFK - Backup camera											V																						
S-CLASS	221		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
S-CLASS	221		Information	NSA - Night View Assist																																	
S-CLASS	221		Information	NBR-LF - Left front range radar																																	
S-CLASS	221		Information	NAV - Navigation module																																	
S-CLASS	221		Information	MIF/UCI - Media interface																																	
S-CLASS	221		Information	ICI - InCar Internet																																	
S-CLASS	221		Information	IC - Instrument cluster																																	
S-CLASS	221		Information	DVD player																																	
S-CLASS	221		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	221		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	221		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	221		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	221		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	221		Information	AVE-H - Rear audio video unit																																	
S-CLASS	221		Information	AUDIO/COMAND	V																																
S-CLASS	221		Information	ASSYST PLUS - PLUS Active Service System																																	
S-CLASS	221		Information	ASSYST Active Service System																																	
S-CLASS	221		Seat/Door	TSG-MR - Right center door control unit																																	
S-CLASS	221		Seat/Door	TSG-ML - Left center door control unit																																	
S-CLASS	221		Seat/Door	TLC/GTO - Garage door opener																																	
S-CLASS	221		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	221		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
S-CLASS	221		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
S-CLASS	221		Seat/Door	HKS - Tailgate control																										V	V				V	
S-CLASS	221		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	221		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	221		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	221		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	221		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	221		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	221		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	221		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	221		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	221		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	221		Air Conditioning	HBF - Rear control panel																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
S-CLASS	221		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	217		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	217		Drive	SG-EM - Power electronics																																	
S-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	217		Drive	DTR - Distronic																																	
S-CLASS	217		Drive	ISM - Intelligent servo module																																	
S-CLASS	217		Drive	PTCU - Common powertrain controller																																	
S-CLASS	217		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
S-CLASS	217		Drive	ETC - Electronic transmission control												V																	V			
S-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	217		Chassis	ABS/ESP - Electronic stability program																	V	V			V												
S-CLASS	217		Chassis	ES - Electrical power steering																																	
S-CLASS	217		Chassis	Suspension																																	
S-CLASS	217		Chassis	EFB - Electric parking brake																																	
S-CLASS	217		Information	TPAD - Touchpad																																	
S-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	217		Information	360' - Camera																																	
S-CLASS	217		Information	SOUND - Sound system																																	
S-CLASS	217		Information	RFK - Backup camera																																	
S-CLASS	217		Information	SGR - Radar sensors control unit																																	
S-CLASS	217		Information	PTS - Parktronic system																																	
S-CLASS	217		Information	NSA - Night View Assist																																	
S-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	217		Information	NBR-RF - Right front range radar																																	
S-CLASS	217		Information	NBR-LF - Left front range radar																																	
S-CLASS	217		Information	MFK - Multifunction camera																																	
S-CLASS	217		Information	Head-up display																																	
S-CLASS	217		Information	AUDIO/COMAND																																	
S-CLASS	217		Information	ZAN - Audio/COMAND display																																	
S-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	217		Information	KAB - Camera cover																																	
S-CLASS	217		Information	IC - Instrument cluster			V																														
S-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	217		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
S-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	AB - Airbag																																	
S-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	217		Body	BNS/BMS - Battery sensor																																	
S-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	217		Seat/Door	HKS - Tailgate control																																	V
S-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
S-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																							V										
S-CLASS	222		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	222		Drive	SG-EM - Power electronics																																	
S-CLASS	222		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	222		Drive	DTR - Distronic																																	
S-CLASS	222		Drive	ISM - Intelligent servo module																																	
S-CLASS	222		Drive	PTCU - Common powertrain controller																																	
S-CLASS	222		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
S-CLASS	222		Drive	ETC - Electronic transmission control												V																	V				
S-CLASS	222		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	222		Chassis	ES - Electrical power steering																																	
S-CLASS	222		Chassis	ABS/ESP - Electronic stability program																	V	V			V												
S-CLASS	222		Chassis	Suspension																																	
S-CLASS	222		Chassis	EFB - Electric parking brake																																	
S-CLASS	222		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
S-CLASS	222		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	222		Information	360' - Camera																																	
S-CLASS	222		Information	Sound generator for exhaust system																																	
S-CLASS	222		Information	SOUND - Sound system																																	
S-CLASS	222		Information	RFK - Backup camera																																	
S-CLASS	222		Information	SGR - Radar sensors control unit																																	
S-CLASS	222		Information	PTS - Parktronic system																																	
S-CLASS	222		Information	NSA - Night View Assist																																	
S-CLASS	222		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
S-CLASS	222		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
S-CLASS	222		Information	NBR-RF - Right front range radar																																	
S-CLASS	222		Information	NBR-LF - Left front range radar																																	
S-CLASS	222		Information	MFK - Multifunction camera																																	
S-CLASS	222		Information	Head-up display																																	
S-CLASS	222		Information	AUDIO/COMAND																																	
S-CLASS	222		Information	AVE-H - Rear audio video unit																																	
S-CLASS	222		Information	ZAN - Audio/COMAND display																																	
S-CLASS	222		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	222		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	222		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	222		Information	KAB - Camera cover																																	
S-CLASS	222		Information	IC - Instrument cluster			V																														
S-CLASS	222		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	222		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
S-CLASS	222		Body	AHE - Trailer recognition																																	
S-CLASS	222		Body	SCM [MRM] - Steering column module																																	
S-CLASS	222		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	222		Body	AB - Airbag																																	
S-CLASS	222		Body	Multifunction control unit																																	
S-CLASS	222		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	222		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	222		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	222		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
S-CLASS	222		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	222		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
S-CLASS	222		Body	BNS/BMS - Battery sensor																																	
S-CLASS	222		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	222		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	222		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	222		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	222		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
S-CLASS	222		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
S-CLASS	222		Seat/Door	HKS - Tailgate control																																	V
S-CLASS	222		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	222		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	222		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	222		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	222		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	222		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	222		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	222		Air Conditioning	AAC - Automatic air conditioning																							V										
G-CLASS	461 - 38P Connector		Drive	EVE																																	
G-CLASS	461 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 38P Connector		Information	IC - Instrument cluster				V																													
G-CLASS	461 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	461 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
G-CLASS	461 - 16P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	461 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	461 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	461 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	461 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	461 - 16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
G-CLASS	461 - 16P Connector		Body	CGW - Central gateway																																	
G-CLASS	461 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 16P Connector		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
G-CLASS	461 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	461 - 16P Connector		Information	AUDIO/COMAND																																	
G-CLASS	461 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 38P Connector		Drive	ME/CDI/CNG - Engine control unit																																	
G-CLASS	463 - 38P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	463 - 38P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 38P Connector		Drive	CC - Cruise control																																	
G-CLASS	463 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	463 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 38P Connector		Information	IC - Instrument cluster					V			V																									
G-CLASS	463 - 38P Connector		Information	AUDIO/COMAND																																	
G-CLASS	463 - 38P Connector		Information	APS - Auto pilot system																																	
G-CLASS	463 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit															V	V			V	V		V		V		V					V		
G-CLASS	463 - 16P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	463 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	463 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	463 - 16P Connector		Drive	SCR - Selective catalytic reduction																																	
G-CLASS	463 - 16P Connector		Drive	ISM - Intelligent servo module																																	
G-CLASS	463 - 16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
G-CLASS	463 - 16P Connector		Drive	DTR - Distronic																																	
G-CLASS	463 - 16P Connector		Drive	DSI - Direct select interface																																	
G-CLASS	463 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	463 - 16P Connector		Chassis	TPM - Tire pressure monitor																																	
G-CLASS	463 - 16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
G-CLASS	463 - 16P Connector		Body	UCP - Upper control panel																																	
G-CLASS	463 - 16P Connector		Body	SCM [MRM] - Steering column module																																	
G-CLASS	463 - 16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
G-CLASS	463 - 16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
G-CLASS	463 - 16P Connector		Body	OCP - Overhead control panel																																	
G-CLASS	463 - 16P Connector		Body	Multifunction control unit																																	
G-CLASS	463 - 16P Connector		Body	HSW/LRH - Steering wheel heater																																	
G-CLASS	463 - 16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
G-CLASS	463 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	463 - 16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
G-CLASS	463 - 16P Connector		Body	AHE - Trailer recognition																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
G-CLASS	463 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 16P Connector		Information	ZAN - Audio/COMAND display																																	
G-CLASS	463 - 16P Connector		Information	TV - TV tuner																																	
G-CLASS	463 - 16P Connector		Information	SOUND - Sound system																																	
G-CLASS	463 - 16P Connector		Information	PTS - Parktronic system																																	
G-CLASS	463 - 16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NAV - Navigation module																																	
G-CLASS	463 - 16P Connector		Information	MIF/UCI - Media interface																																	
G-CLASS	463 - 16P Connector		Information	IC - Instrument cluster			V																														
G-CLASS	463 - 16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
G-CLASS	463 - 16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
G-CLASS	463 - 16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
G-CLASS	463 - 16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
G-CLASS	463 - 16P Connector		Information	AUDIO/COMAND	V																																
G-CLASS	463 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	463 - 16P Connector		Seat/Door	HS - Seat heater																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RR - Door control module rear right																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RL - Door control module rear left																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FR - Door control module front right																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FL - Door control module front left																																	
G-CLASS	463 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Air Conditioning	AAC - Automatic air conditioning														V								V											
GLA-CLASS	156		Drive	VG - Transfer case																																	
GLA-CLASS	156		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V			
GLA-CLASS	156		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLA-CLASS	156		Drive	ETC - Electronic transmission control												V																		V			
GLA-CLASS	156		Drive	DTR - Distronic																																	
GLA-CLASS	156		Drive	DSI - Direct select interface																																	
GLA-CLASS	156		Drive	PTCU - Common powertrain controller																																	
GLA-CLASS	156		Chassis	ABS/ESP - Electronic stability program																																	
GLA-CLASS	156		Chassis	ES - Electrical power steering																																	
GLA-CLASS	156		Chassis	EFB - Electric parking brake																																	
GLA-CLASS	156		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
GLA-CLASS	156		Body	SG-AWF - Collision prevention assist																																	
GLA-CLASS	156		Body	SCM [MRM] - Steering column module																																	
GLA-CLASS	156		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLA-CLASS	156		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	Multifunction control unit																																	
GLA-CLASS	156		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLA-CLASS	156		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLA-CLASS	156		Body	EZS/EIS - Electronic ignition lock																																	
GLA-CLASS	156		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLA-CLASS	156		Body	AHE - Trailer recognition																																	
GLA-CLASS	156		Body	AB - Airbag																																	
GLA-CLASS	156		Information	Head-up display																																	
GLA-CLASS	156		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLA-CLASS	156		Information	KAB - Camera cover																																	
GLA-CLASS	156		Information	ZAN - Audio/COMAND display																																	
GLA-CLASS	156		Information	TV - TV tuner																																	
GLA-CLASS	156		Information	SOUND - Sound system																																	
GLA-CLASS	156		Information	RFK - Backup camera																																	
GLA-CLASS	156		Information	MFK - Multifunction camera																																	
GLA-CLASS	156		Information	PTS - Parktronic system																																	
GLA-CLASS	156		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLA-CLASS	156		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLA-CLASS	156		Information	NAV - Navigation module																																	
GLA-CLASS	156		Information	MIF/UCI - Media interface																																	
GLA-CLASS	156		Information	IC - Instrument cluster			V																														
GLA-CLASS	156		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLA-CLASS	156		Information	DAB/SDAR - Digital/Satellite radio																																	
GLA-CLASS	156		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLA-CLASS	156		Information	AUDIO/COMAND	V																																
GLA-CLASS	156		Seat/Door	HKS - Tailgate control																										V	V				V	
GLA-CLASS	156		Seat/Door	PSD/MSC - Sliding roof control																																	
GLA-CLASS	156		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLA-CLASS	156		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLA-CLASS	156		Seat/Door	DCM-FR - Door control module front right																																	
GLA-CLASS	156		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
GLA-CLASS	156		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLA-CLASS	156		Air Conditioning	AAC - Automatic air conditioning														V									V										
GLK-CLASS	204		Drive	ME/CDI/CNG - Engine control unit															V	V			V	V		V		V		V					V		
GLK-CLASS	204		Drive	ETC - Electronic transmission control												V																		V			
GLK-CLASS	204		Drive	ESM - Electronic selector module																																	
GLK-CLASS	204		Drive	SCR - Selective catalytic reduction																																	
GLK-CLASS	204		Drive	PTCU - Common powertrain controller																																	
GLK-CLASS	204		Drive	ISM - Intelligent servo module																																	
GLK-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
GLK-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLK-CLASS	204		Drive	DTR - Distronic																																	
GLK-CLASS	204		Drive	AMG DRIVE UNIT																																	
GLK-CLASS	204		Chassis	ABS/ESP - Electronic stability program																																	
GLK-CLASS	204		Chassis	Suspension																																	
GLK-CLASS	204		Chassis	ES - Electrical power steering																																	
GLK-CLASS	204		Chassis	TPM - Tire pressure monitor																																	
GLK-CLASS	204		Body	WSS - Weight sensing system																																	
GLK-CLASS	204		Body	SCM [MRM] - Steering column module																																	
GLK-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLK-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLK-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	OCP - Overhead control panel																																	
GLK-CLASS	204		Body	Multifunction control unit																																	
GLK-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLK-CLASS	204		Body	Headlamp-R - Headlamp control unit																																	
GLK-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLK-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	
GLK-CLASS	204		Body	CGW - Central gateway																																	
GLK-CLASS	204		Body	AHE - Trailer recognition																																	
GLK-CLASS	204		Body	AB - Airbag																																	
GLK-CLASS	204		Information	Head-up display																																	
GLK-CLASS	204		Information	AVE-H - Rear audio video unit																																	
GLK-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLK-CLASS	204		Information	ZAN - Audio/COMAND display																																	
GLK-CLASS	204		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
GLK-CLASS	204		Information	Sound generator for exhaust system																																	
GLK-CLASS	204		Information	SOUND - Sound system																																	
GLK-CLASS	204		Information	SGR - Radar sensors control unit																																	
GLK-CLASS	204		Information	360' - Camera																																	
GLK-CLASS	204		Information	MFK - Multifunction camera																																	
GLK-CLASS	204		Information	RFK - Backup camera											V																						
GLK-CLASS	204		Information	PTS - Parktronic system																																	
GLK-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLK-CLASS	204		Information	NBR-RF - Right front range radar																																	
GLK-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLK-CLASS	204		Information	NBR-LF - Left front range radar																																	
GLK-CLASS	204		Information	NAV - Navigation module																																	
GLK-CLASS	204		Information	MIF/UCI - Media interface																																	
GLK-CLASS	204		Information	ICI - InCar Internet																																	
GLK-CLASS	204		Information	IC - Instrument cluster			V																														
GLK-CLASS	204		Information	DVD player																																	
GLK-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLK-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
GLK-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
GLK-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
GLK-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GLK-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLK-CLASS	204		Information	AUDIO/COMAND	V																																
GLK-CLASS	204		Information	AMG Performance Media																																	
GLK-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
GLK-CLASS	204		Seat/Door	HKS - Tailgate control																											V	V				V	
GLK-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLK-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLK-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
GLK-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
GLK-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
GLK-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
GLK-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLK-CLASS	204		Air Conditioning	AAC - Automatic air conditioning														V								V											
GLC-CLASS	253		Drive	SCR - Selective catalytic reduction																																	
GLC-CLASS	253		Drive	SG-EM - Power electronics																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
GLC-CLASS	253		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLC-CLASS	253		Drive	DTR - Distronic																																	
GLC-CLASS	253		Drive	ISM - Intelligent servo module																																	
GLC-CLASS	253		Drive	PTCU - Common powertrain controller																																	
GLC-CLASS	253		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
GLC-CLASS	253		Drive	ETC - Electronic transmission control												V																	V			
GLC-CLASS	253		Chassis	TPM - Tire pressure monitor																																	
GLC-CLASS	253		Chassis	AIRMATIC PLUS																																	
GLC-CLASS	253		Chassis	ES - Electrical power steering																																	
GLC-CLASS	253		Chassis	Suspension																																	
GLC-CLASS	253		Chassis	ABS/ESP - Electronic stability program																	V	V			V												
GLC-CLASS	253		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLC-CLASS	253		Body	AHE - Trailer recognition																																	
GLC-CLASS	253		Body	SCM [MRM] - Steering column module																																	
GLC-CLASS	253		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	AB - Airbag																																	
GLC-CLASS	253		Body	Multifunction control unit																																	
GLC-CLASS	253		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLC-CLASS	253		Body	Headlamp-R - Headlamp control unit																																	
GLC-CLASS	253		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLC-CLASS	253		Body	SG-AWF - Collision prevention assist																																	
GLC-CLASS	253		Body	EZS/EIS - Electronic ignition lock																																	
GLC-CLASS	253		Body	BNS/BMS - Battery sensor																																	
GLC-CLASS	253		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLC-CLASS	253		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLC-CLASS	253		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLC-CLASS	253		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLC-CLASS	253		Seat/Door	PSD/MSC - Sliding roof control																																	
GLC-CLASS	253		Seat/Door	HKS - Tailgate control																																	V
GLC-CLASS	253		Seat/Door	DCM-RR - Door control module rear right																																	
GLC-CLASS	253		Seat/Door	DCM-RL - Door control module rear left																																	
GLC-CLASS	253		Seat/Door	DCM-FR - Door control module front right																																	
GLC-CLASS	253		Seat/Door	DCM-FL - Door control module front left																																	
GLC-CLASS	253		Information	TPAD - Touchpad																																	
GLC-CLASS	253		Information	DAB/SDAR - Digital/Satellite radio																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
GLC-CLASS	253		Information	360' - Camera																																	
GLC-CLASS	253		Information	Sound generator for exhaust system																																	
GLC-CLASS	253		Information	SOUND - Sound system																																	
GLC-CLASS	253		Information	RFK - Backup camera																																	
GLC-CLASS	253		Information	SGR - Radar sensors control unit																																	
GLC-CLASS	253		Information	PTS - Parktronic system																																	
GLC-CLASS	253		Information	NBR-RF - Right front range radar																																	
GLC-CLASS	253		Information	NBR-LF - Left front range radar																																	
GLC-CLASS	253		Information	MFK - Multifunction camera																																	
GLC-CLASS	253		Information	IC - Instrument cluster			V																														
GLC-CLASS	253		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLC-CLASS	253		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLC-CLASS	253		Information	Head-up display																																	
GLC-CLASS	253		Information	AUDIO/COMAND																																	
GLC-CLASS	253		Information	SG-MSND - Engine sound																																	
GLC-CLASS	253		Information	ZAN - Audio/COMAND display																																	
GLC-CLASS	253		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLC-CLASS	253		Information	KAB - Camera cover																																	
GLC-CLASS	253		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLC-CLASS	253		Information	AMG Performance Media																																	
GLC-CLASS	253		Air Conditioning	AAC - Automatic air conditioning																						V											
GLE-CLASS	292		Drive	SCR - Selective catalytic reduction																																	
GLE-CLASS	292		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLE-CLASS	292		Drive	ISM - Intelligent servo module																																	
GLE-CLASS	292		Drive	DTR - Distronic																																	
GLE-CLASS	292		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
GLE-CLASS	292		Drive	ETC - Electronic transmission control												V																	V				
GLE-CLASS	292		Chassis	TPM - Tire pressure monitor																																	
GLE-CLASS	292		Chassis	FWGW - Chassis gateway																																	
GLE-CLASS	292		Chassis	ABS/ESP - Electronic stability program																																	
GLE-CLASS	292		Chassis	ES - Electrical power steering																																	
GLE-CLASS	292		Chassis	EFB - Electric parking brake																																	
GLE-CLASS	292		Chassis	Suspension																																	
GLE-CLASS	292		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLE-CLASS	292		Body	AHE - Trailer recognition																																	
GLE-CLASS	292		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
GLE-CLASS	292		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLE-CLASS	292		Body	AB - Airbag																																	
GLE-CLASS	292		Body	Multifunction control unit																																	
GLE-CLASS	292		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLE-CLASS	292		Body	Headlamp-R - Headlamp control unit																																	
GLE-CLASS	292		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLE-CLASS	292		Body	SG-AWF - Collision prevention assist																																	
GLE-CLASS	292		Body	EZS/EIS - Electronic ignition lock																																	
GLE-CLASS	292		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLE-CLASS	292		Information	TPAD - Touchpad																																	
GLE-CLASS	292		Information	DAB/SDAR - Digital/Satellite radio																																	
GLE-CLASS	292		Information	360' - Camera																																	
GLE-CLASS	292		Information	SOUND - Sound system																																	
GLE-CLASS	292		Information	RFK - Backup camera																																	
GLE-CLASS	292		Information	SGR - Radar sensors control unit																																	
GLE-CLASS	292		Information	PTS - Parktronic system																																	
GLE-CLASS	292		Information	MFK - Multifunction camera																																	
GLE-CLASS	292		Information	NBR-RF - Right front range radar																																	
GLE-CLASS	292		Information	NBR-LF - Left front range radar																																	
GLE-CLASS	292		Information	IC - Instrument cluster			V																														
GLE-CLASS	292		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLE-CLASS	292		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLE-CLASS	292		Information	Head-up display																																	
GLE-CLASS	292		Information	AUDIO/COMAND																																	
GLE-CLASS	292		Information	AVE-H - Rear audio video unit																																	
GLE-CLASS	292		Information	DVD player																																	
GLE-CLASS	292		Information	SG-MSND - Engine sound																																	
GLE-CLASS	292		Information	ZAN - Audio/COMAND display																																	
GLE-CLASS	292		Information	D-FOR - Display in right rear passenger																																	
GLE-CLASS	292		Information	D-FOL - Display in left rear passenger																																	
GLE-CLASS	292		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLE-CLASS	292		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GLE-CLASS	292		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLE-CLASS	292		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
GLE-CLASS	292		Seat/Door	PSD/MSC - Sliding roof control																																	
GLE-CLASS	292		Seat/Door	HKS - Tailgate control																											V	V				V	
GLE-CLASS	292		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DCM-RR - Door control module rear right																																	
GLE-CLASS	292		Seat/Door	DCM-RL - Door control module rear left																																	
GLE-CLASS	292		Seat/Door	DCM-FR - Door control module front right																																	
GLE-CLASS	292		Seat/Door	DCM-FL - Door control module front left																																	
GLE-CLASS	292		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLE-CLASS	292		Air Conditioning	HBF - Rear control panel																																	
GLE-CLASS	292		Air Conditioning	AAC - Automatic air conditioning														V								V											
GL-CLASS	164		Drive	ME/CDI/CNG - Engine control unit															V	V			V	V		V		V		V						V	
GL-CLASS	164		Drive	ETC - Electronic transmission control												V																		V			
GL-CLASS	164		Drive	VG - Transfer case																																	
GL-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
GL-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
GL-CLASS	164		Drive	SCR - Selective catalytic reduction																																	
GL-CLASS	164		Drive	ISM - Intelligent servo module																																	
GL-CLASS	164		Drive	HSG - Hybrid control unit																	V	V			V												
GL-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
GL-CLASS	164		Drive	DTR - Distronic																																	
GL-CLASS	164		Chassis	ABS/ESP - Electronic stability program																																	
GL-CLASS	164		Chassis	Suspension																																	
GL-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
GL-CLASS	164		Chassis	ES - Electrical power steering																																	
GL-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	164		Body	WSS - Weight sensing system																																	
GL-CLASS	164		Body	UCP - Upper control panel																																	
GL-CLASS	164		Body	System diagnosis																																	
GL-CLASS	164		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GL-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
GL-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
GL-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	164		Body	CGW - Central gateway																																	
GL-CLASS	164		Body	AB - Airbag																																	
GL-CLASS	164		Information	TV - TV tuner																																	
GL-CLASS	164		Information	SOUND - Sound system																																	
GL-CLASS	164		Information	RFK - Backup camera											V																						
GL-CLASS	164		Information	PTS - Parktronic system																																	
GL-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	164		Information	NAV - Navigation module																																	
GL-CLASS	164		Information	MIF/UCI - Media interface																																	
GL-CLASS	164		Information	IC - Instrument cluster																																	
GL-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GL-CLASS	164		Information	CM - Compass module																																	
GL-CLASS	164		Information	AVE-H - Rear audio video unit																																	
GL-CLASS	164		Information	AUDIO/COMAND																																	
GL-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
GL-CLASS	164		Information	ASSYST Active Service System																																	
GL-CLASS	164		Information	AGW - Audio gateway																																	
GL-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
GL-CLASS	164		Seat/Door	HS - Seat heater																																	
GL-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
GL-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
GL-CLASS	164		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GL-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
GL-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
GL-CLASS	166		Drive	SG-EM - Power electronics																																	
GL-CLASS	166		Drive	PTCU - Common powertrain controller																																	
GL-CLASS	166		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
GL-CLASS	166		Drive	ETC - Electronic transmission control												V																	V			
GL-CLASS	166		Drive	VG - Transfer case																																	
GL-CLASS	166		Drive	SCR - Selective catalytic reduction																																	
GL-CLASS	166		Drive	ISM - Intelligent servo module																																	
GL-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	166		Drive	DTR - Distronic																																	
GL-CLASS	166		Chassis	ABS/ESP - Electronic stability program																																	
GL-CLASS	166		Chassis	Suspension																																	
GL-CLASS	166		Chassis	ES - Electrical power steering																																	
GL-CLASS	166		Chassis	EFB - Electric parking brake																																	
GL-CLASS	166		Chassis	FWGW - Chassis gateway																																	
GL-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
GL-CLASS	166		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GL-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	Multifunction control unit																																	
GL-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GL-CLASS	166		Body	AHE - Trailer recognition																																	
GL-CLASS	166		Body	AB - Airbag																																	
GL-CLASS	166		Information	Sound generator for exhaust system																																	
GL-CLASS	166		Information	Head-up display																																	
GL-CLASS	166		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
GL-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GL-CLASS	166		Information	ZAN - Audio/COMAND display																																	
GL-CLASS	166		Information	TV - TV tuner																																	
GL-CLASS	166		Information	SOUND - Sound system																																	
GL-CLASS	166		Information	SGR - Radar sensors control unit																																	
GL-CLASS	166		Information	360' - Camera																																	
GL-CLASS	166		Information	RFK - Backup camera																																	
GL-CLASS	166		Information	MFK - Multifunction camera																																	
GL-CLASS	166		Information	PTS - Parktronic system																																	
GL-CLASS	166		Information	NSA - Night View Assist																																	
GL-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	166		Information	NBR-RF - Right front range radar																																	
GL-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	166		Information	NBR-LF - Left front range radar																																	
GL-CLASS	166		Information	NAV - Navigation module																																	
GL-CLASS	166		Information	MIF/UCI - Media interface																																	
GL-CLASS	166		Information	IC - Instrument cluster			V																														
GL-CLASS	166		Information	DVD player																																	
GL-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GL-CLASS	166		Information	AUDIO/COMAND	V																																
GL-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
GL-CLASS	166		Seat/Door	HKS - Tailgate control																											V	V				V	
GL-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
GL-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
GL-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
GL-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
GL-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
GL-CLASS	166		Air Conditioning	AAC - Automatic air conditioning														V									V										
M-CLASS	163		Drive	ME/CDI/CNG - Engine control unit																																	
M-CLASS	163		Drive	ETC - Electronic transmission control																																	
M-CLASS	163		Drive	ESM - Electronic selector module																																	
M-CLASS	163		Drive	VG - Transfer case																																	
M-CLASS	163		Chassis	ABS/ESP - Electronic stability program																																	
M-CLASS	163		Chassis	VP - Vacuum pump brake booster																																	
M-CLASS	163		Chassis	BAS - Brake assist																																	
M-CLASS	163		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	163		Body	AB - Airbag																																	
M-CLASS	163		Body	AAM - All activity module																																	
M-CLASS	163		Information	PTS - Parktronic system																																	
M-CLASS	163		Information	IC - Instrument cluster					V			V																									
M-CLASS	163		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	163		Information	AUDIO/COMAND																																	
M-CLASS	163		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	163		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Drive	ME/CDI/CNG - Engine control unit															V	V			V	V		V		V		V					V		
M-CLASS	164		Drive	ETC - Electronic transmission control												V																	V			
M-CLASS	164		Drive	VG - Transfer case																																	
M-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
M-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
M-CLASS	164		Drive	SCR - Selective catalytic reduction																																	
M-CLASS	164		Drive	ISM - Intelligent servo module																																	
M-CLASS	164		Drive	HSG - Hybrid control unit																	V	V			V												
M-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
M-CLASS	164		Drive	DTR - Distronic																																	
M-CLASS	164		Chassis	ABS/ESP - Electronic stability program																																	
M-CLASS	164		Chassis	Suspension																																	
M-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
M-CLASS	164		Chassis	ES - Electrical power steering																																	
M-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	164		Body	WSS - Weight sensing system																																	
M-CLASS	164		Body	UCP - Upper control panel																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
M-CLASS	164		Body	System diagnosis																																	
M-CLASS	164		Body	SCM [MRM] - Steering column module																																	
M-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
M-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	OCP - Overhead control panel																																	
M-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
M-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	164		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	164		Body	CGW - Central gateway																																	
M-CLASS	164		Body	AB - Airbag																																	
M-CLASS	164		Information	TV - TV tuner																																	
M-CLASS	164		Information	SOUND - Sound system																																	
M-CLASS	164		Information	RFK - Backup camera											V																						
M-CLASS	164		Information	PTS - Parktronic system																																	
M-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	164		Information	NAV - Navigation module																																	
M-CLASS	164		Information	MIF/UCI - Media interface																																	
M-CLASS	164		Information	IC - Instrument cluster																																	
M-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
M-CLASS	164		Information	CM - Compass module																																	
M-CLASS	164		Information	AVE-H - Rear audio video unit																																	
M-CLASS	164		Information	AUDIO/COMAND																																	
M-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
M-CLASS	164		Information	ASSYST Active Service System																																	
M-CLASS	164		Information	AGW - Audio gateway																																	
M-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
M-CLASS	164		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
M-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
M-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	164		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
M-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	166		Drive	SG-EM - Power electronics																																	
M-CLASS	166		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
M-CLASS	166		Drive	ETC - Electronic transmission control												V																	V			
M-CLASS	166		Drive	VG - Transfer case																																	
M-CLASS	166		Drive	SCR - Selective catalytic reduction																																	
M-CLASS	166		Drive	PTCU - Common powertrain controller																																	
M-CLASS	166		Drive	ISM - Intelligent servo module																																	
M-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	166		Drive	DTR - Distronic																																	
M-CLASS	166		Chassis	ABS/ESP - Electronic stability program																																	
M-CLASS	166		Chassis	Suspension																																	
M-CLASS	166		Chassis	ES - Electrical power steering																																	
M-CLASS	166		Chassis	EFB - Electric parking brake																																	
M-CLASS	166		Chassis	FWGW - Chassis gateway																																	
M-CLASS	166		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
M-CLASS	166		Body	SCM [MRM] - Steering column module																																	
M-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
M-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	Multifunction control unit																																	
M-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
M-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
M-CLASS	166		Body	AHE - Trailer recognition																																	
M-CLASS	166		Body	AB - Airbag																																	
M-CLASS	166		Information	Sound generator for exhaust system																																	
M-CLASS	166		Information	Head-up display																																	
M-CLASS	166		Information	AVE-H - Rear audio video unit																																	
M-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
M-CLASS	166		Information	ZAN - Audio/COMAND display																																	
M-CLASS	166		Information	TV - TV tuner																																	
M-CLASS	166		Information	SOUND - Sound system																																	
M-CLASS	166		Information	SGR - Radar sensors control unit																																	
M-CLASS	166		Information	360' - Camera																																	
M-CLASS	166		Information	RFK - Backup camera																																	
M-CLASS	166		Information	MFK - Multifunction camera																																	
M-CLASS	166		Information	PTS - Parktronic system																																	
M-CLASS	166		Information	NSA - Night View Assist																																	
M-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	166		Information	NBR-RF - Right front range radar																																	
M-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	166		Information	NBR-LF - Left front range radar																																	
M-CLASS	166		Information	NAV - Navigation module																																	
M-CLASS	166		Information	MIF/UCI - Media interface																																	
M-CLASS	166		Information	IC - Instrument cluster			V																														
M-CLASS	166		Information	DVD player																																	
M-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
M-CLASS	166		Information	AUDIO/COMAND	V																																
M-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
M-CLASS	166		Seat/Door	HKS - Tailgate control																											V	V				V	
M-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
M-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
M-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
M-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
M-CLASS	166		Air Conditioning	AAC - Automatic air conditioning														V								V											
R-CLASS	251		Drive	ME/CDI/CNG - Engine control unit															V	V			V	V		V		V		V					V		
R-CLASS	251		Drive	ETC - Electronic transmission control																																	
R-CLASS	251		Drive	SCR - Selective catalytic reduction																																	
R-CLASS	251		Drive	ISM - Intelligent servo module																																	
R-CLASS	251		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
R-CLASS	251		Drive	DTR - Distronic																																	
R-CLASS	251		Chassis	ABS/ESP - Electronic stability program																																	
R-CLASS	251		Chassis	Suspension																																	
R-CLASS	251		Chassis	ES - Electrical power steering																																	
R-CLASS	251		Chassis	TPM - Tire pressure monitor																																	
R-CLASS	251		Body	WSS - Weight sensing system																																	
R-CLASS	251		Body	UCP - Upper control panel																																	
R-CLASS	251		Body	System diagnosis																																	
R-CLASS	251		Body	SCM [MRM] - Steering column module																																	
R-CLASS	251		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
R-CLASS	251		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
R-CLASS	251		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	OCP - Overhead control panel																																	
R-CLASS	251		Body	LCP/HBF - Lower/Rear control panel																																	
R-CLASS	251		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
R-CLASS	251		Body	Headlamp-R - Headlamp control unit																																	
R-CLASS	251		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
R-CLASS	251		Body	EZS/EIS - Electronic ignition lock																																	
R-CLASS	251		Body	CGW - Central gateway																																	
R-CLASS	251		Body	AB - Airbag																																	
R-CLASS	251		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
R-CLASS	251		Information	SOUND - Sound system																																	
R-CLASS	251		Information	RFK - Backup camera											V																						
R-CLASS	251		Information	PTS - Parktronic system																																	
R-CLASS	251		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
R-CLASS	251		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
R-CLASS	251		Information	NAV - Navigation module																																	
R-CLASS	251		Information	MIF/UCI - Media interface																																	
R-CLASS	251		Information	IC - Instrument cluster																																	
R-CLASS	251		Information	DTA - Mbrace or TELEAID/GPS Box																																	
R-CLASS	251		Information	D-FOR - Display in right rear passenger																																	
R-CLASS	251		Information	D-FOL - Display in left rear passenger																																	
R-CLASS	251		Information	DAB/SDAR - Digital/Satellite radio																																	
R-CLASS	251		Information	CTEL/TEL - Cellular/Mobile telephone																																	
R-CLASS	251		Information	CM - Compass module																																	
R-CLASS	251		Information	AVE-H - Rear audio video unit																																	
R-CLASS	251		Information	AUDIO/COMAND																																	
R-CLASS	251		Information	ASSYST PLUS - PLUS Active Service System																																	
R-CLASS	251		Information	ASSYST Active Service System																																	
R-CLASS	251		Information	AGW - Audio gateway																																	
R-CLASS	251		Seat/Door	REDC/RWT - Rear end door control module																																	
R-CLASS	251		Seat/Door	HS - Seat heater																																	
R-CLASS	251		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
R-CLASS	251		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
R-CLASS	251		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
R-CLASS	251		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DCM-FR - Door control module front right																																	
R-CLASS	251		Seat/Door	DCM-FL - Door control module front left																																	
R-CLASS	251		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
R-CLASS	251		Air Conditioning	AAC - Automatic air conditioning																																	
CLA-CLASS	117		Drive	VG - Transfer case																																	
CLA-CLASS	117		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
CLA-CLASS	117		Drive	ETC - Electronic transmission control												V																	V			
CLA-CLASS	117		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLA-CLASS	117		Drive	DTR - Distronic																																	
CLA-CLASS	117		Drive	DSI - Direct select interface																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
CLA-CLASS	117		Drive	PTCU - Common powertrain controller																																	
CLA-CLASS	117		Chassis	ABS/ESP - Electronic stability program																																	
CLA-CLASS	117		Chassis	ES - Electrical power steering																																	
CLA-CLASS	117		Chassis	EFB - Electric parking brake																																	
CLA-CLASS	117		Chassis	TPM - Tire pressure monitor																																	
CLA-CLASS	117		Body	SG-AWF - Collision prevention assist																																	
CLA-CLASS	117		Body	SCM [MRM] - Steering column module																																	
CLA-CLASS	117		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLA-CLASS	117		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	Multifunction control unit																																	
CLA-CLASS	117		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLA-CLASS	117		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLA-CLASS	117		Body	EZS/EIS - Electronic ignition lock																																	
CLA-CLASS	117		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CLA-CLASS	117		Body	AHE - Trailer recognition																																	
CLA-CLASS	117		Body	AB - Airbag																																	
CLA-CLASS	117		Information	Head-up display																																	
CLA-CLASS	117		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLA-CLASS	117		Information	KAB - Camera cover																																	
CLA-CLASS	117		Information	ZAN - Audio/COMAND display																																	
CLA-CLASS	117		Information	TV - TV tuner																																	
CLA-CLASS	117		Information	SOUND - Sound system																																	
CLA-CLASS	117		Information	RFK - Backup camera																																	
CLA-CLASS	117		Information	MFK - Multifunction camera																																	
CLA-CLASS	117		Information	PTS - Parktronic system																																	
CLA-CLASS	117		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLA-CLASS	117		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLA-CLASS	117		Information	NAV - Navigation module																																	
CLA-CLASS	117		Information	MIF/UCI - Media interface																																	
CLA-CLASS	117		Information	IC - Instrument cluster			V																														
CLA-CLASS	117		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLA-CLASS	117		Information	DAB/SDAR - Digital/Satellite radio																																	
CLA-CLASS	117		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLA-CLASS	117		Information	AUDIO/COMAND	V																																
CLA-CLASS	117		Seat/Door	HKS - Tailgate control																											V	V				V	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
CLA-CLASS	117		Seat/Door	PSD/MSC - Sliding roof control																																	
CLA-CLASS	117		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLA-CLASS	117		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLA-CLASS	117		Seat/Door	DCM-FR - Door control module front right																																	
CLA-CLASS	117		Seat/Door	DCM-FL - Door control module front left																																	
CLA-CLASS	117		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLA-CLASS	117		Air Conditioning	AAC - Automatic air conditioning														V								V											
CLK-CLASS	208		Drive	ME/CDI/CNG - Engine control unit		V																															
CLK-CLASS	208		Drive	ETC - Electronic transmission control																																	
CLK-CLASS	208		Drive	ESM - Electronic selector module																																	
CLK-CLASS	208		Chassis	PSE - Pneumatic system equipment																																	
CLK-CLASS	208		Chassis	ABS/ESP - Electronic stability program																																	
CLK-CLASS	208		Chassis	VP - Vacuum pump brake booster																																	
CLK-CLASS	208		Chassis	BAS - Brake assist																																	
CLK-CLASS	208		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	208		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	208		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	208		Body	OCP - Overhead control panel																																	
CLK-CLASS	208		Body	AB - Airbag																																	
CLK-CLASS	208		Information	TV - TV tuner																																	
CLK-CLASS	208		Information	PTS - Parktronic system																																	
CLK-CLASS	208		Information	NAV - Navigation module																																	
CLK-CLASS	208		Information	IC - Instrument cluster					V			V																									
CLK-CLASS	208		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	208		Information	AUDIO/COMAND																																	
CLK-CLASS	208		Information	APS - Auto pilot system																																	
CLK-CLASS	208		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	208		Air Conditioning	AAC - Automatic air conditioning																																	
CLK-CLASS	208		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	208		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	208		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	208		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Drive	ME/CDI/CNG - Engine control unit		V																		V													
CLK-CLASS	209		Drive	ETC - Electronic transmission control																																	
CLK-CLASS	209		Drive	ESM - Electronic selector module																																	
CLK-CLASS	209		Drive	DTR - Distronic																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
CLK-CLASS	209		Chassis	ABS/ESP - Electronic stability program																																	
CLK-CLASS	209		Chassis	TPM - Tire pressure monitor																																	
CLK-CLASS	209		Body	WSS - Weight sensing system																																	
CLK-CLASS	209		Body	UCP - Upper control panel																																	
CLK-CLASS	209		Body	SCM [MRM] - Steering column module																																	
CLK-CLASS	209		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLK-CLASS	209		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	209		Body	RCM - Rear control module						V	V																										
CLK-CLASS	209		Body	OCP - Overhead control panel																																	
CLK-CLASS	209		Body	Multifunction control unit																																	
CLK-CLASS	209		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	209		Body	Headlamp-R - Headlamp control unit																																	
CLK-CLASS	209		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLK-CLASS	209		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	209		Body	BNS/BMS - Battery sensor																																	
CLK-CLASS	209		Body	AHE - Trailer recognition																																	
CLK-CLASS	209		Body	AB - Airbag																																	
CLK-CLASS	209		Information	TV - TV tuner																																	
CLK-CLASS	209		Information	PTS - Parktronic system																																	
CLK-CLASS	209		Information	NAV - Navigation module																																	
CLK-CLASS	209		Information	IC - Instrument cluster																																	
CLK-CLASS	209		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	209		Information	AUDIO/COMAND																																	
CLK-CLASS	209		Information	AGW - Audio gateway																																	
CLK-CLASS	209		Seat/Door	RVC/VDS - Convertible roof control						V	V																										
CLK-CLASS	209		Seat/Door	REDC/RWT - Rear end door control module																																	
CLK-CLASS	209		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	209		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	209		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	209		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	209		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	219		Drive	ME/CDI/CNG - Engine control unit																				V													
CLS-CLASS	219		Drive	ETC - Electronic transmission control																																	
CLS-CLASS	219		Drive	ESM - Electronic selector module																																	
CLS-CLASS	219		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
CLS-CLASS	219		Drive	DTR - Distronic																																	
CLS-CLASS	219		Chassis	ABS/ESP - Electronic stability program																																	
CLS-CLASS	219		Chassis	Suspension																																	
CLS-CLASS	219		Chassis	SBC - Sensotronic Brake Control																																	
CLS-CLASS	219		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	219		Body	WSS - Weight sensing system																																	
CLS-CLASS	219		Body	UCP - Upper control panel																																	
CLS-CLASS	219		Body	System diagnosis																																	
CLS-CLASS	219		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	219		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	219		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CLS-CLASS	219		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLS-CLASS	219		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	OCP - Overhead control panel																																	
CLS-CLASS	219		Body	LCP/HBF - Lower/Rear control panel																																	
CLS-CLASS	219		Body	LAE [LAA] - Loading floor automatically extendable																																	
CLS-CLASS	219		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	219		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	219		Body	CGW - Central gateway																																	
CLS-CLASS	219		Body	BNS/BMS - Battery sensor																																	
CLS-CLASS	219		Body	AB - Airbag																																	
CLS-CLASS	219		Information	TV - TV tuner																																	
CLS-CLASS	219		Information	SOUND - Sound system																																	
CLS-CLASS	219		Information	PTS - Parktronic system																																	
CLS-CLASS	219		Information	MIF/UCI - Media interface																																	
CLS-CLASS	219		Information	IC - Instrument cluster																																	
CLS-CLASS	219		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	219		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	219		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	219		Information	AUDIO/COMAND																																	
CLS-CLASS	219		Information	ASSYST PLUS - PLUS Active Service System																																	
CLS-CLASS	219		Information	ASSYST Active Service System																																	
CLS-CLASS	219		Information	AGW - Audio gateway																																	
CLS-CLASS	219		Seat/Door	REDC/RWT - Rear end door control module																																	
CLS-CLASS	219		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
CLS-CLASS	219		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	219		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	219		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	219		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	219		Seat/Door	DCM-RL - Door control module rear left																																	
CLS-CLASS	219		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	219		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	219		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	219		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	218		Drive	ME/CDI/CNG - Engine control unit															V	V			V	V		V		V		V						V		
CLS-CLASS	218		Drive	ETC - Electronic transmission control												V																		V			
CLS-CLASS	218		Drive	ESM - Electronic selector module																																	
CLS-CLASS	218		Drive	SCR - Selective catalytic reduction																																	
CLS-CLASS	218		Drive	ISM - Intelligent servo module																																	
CLS-CLASS	218		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLS-CLASS	218		Drive	DTR - Distronic																																	
CLS-CLASS	218		Drive	DSI - Direct select interface																																	
CLS-CLASS	218		Drive	AMG DRIVE UNIT																																	
CLS-CLASS	218		Chassis	ABS/ESP - Electronic stability program																																	
CLS-CLASS	218		Chassis	Suspension																																	
CLS-CLASS	218		Chassis	ES - Electrical power steering																																	
CLS-CLASS	218		Chassis	FWGW - Chassis gateway																																	
CLS-CLASS	218		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	218		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
CLS-CLASS	218		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
CLS-CLASS	218		Body	WSS - Weight sensing system																																	
CLS-CLASS	218		Body	SG-AWF - Collision prevention assist																																	
CLS-CLASS	218		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	218		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	218		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLS-CLASS	218		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	OCP - Overhead control panel																																	
CLS-CLASS	218		Body	Multifunction control unit																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
CLS-CLASS	218		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLS-CLASS	218		Body	HSW/LRH - Steering wheel heater																																	
CLS-CLASS	218		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
CLS-CLASS	218		Body	Headlamp-R - Headlamp control unit																																	
CLS-CLASS	218		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	218		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	218		Body	CGW - Central gateway																																	
CLS-CLASS	218		Body	AHE - Trailer recognition																																	
CLS-CLASS	218		Body	AB - Airbag																																	
CLS-CLASS	218		Information	360' - Camera																																	
CLS-CLASS	218		Information	AVE-H - Rear audio video unit																																	
CLS-CLASS	218		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLS-CLASS	218		Information	ZAN - Audio/COMAND display																																	
CLS-CLASS	218		Information	TV - TV tuner																																	
CLS-CLASS	218		Information	SOUND - Sound system																																	
CLS-CLASS	218		Information	SGR - Radar sensors control unit																																	
CLS-CLASS	218		Information	MFK - Multifunction camera																																	
CLS-CLASS	218		Information	RFK - Backup camera											V																						
CLS-CLASS	218		Information	PTS - Parktronic system																																	
CLS-CLASS	218		Information	NSA - Night View Assist																																	
CLS-CLASS	218		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLS-CLASS	218		Information	NBR-RF - Right front range radar																																	
CLS-CLASS	218		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLS-CLASS	218		Information	NBR-LF - Left front range radar																																	
CLS-CLASS	218		Information	NAV - Navigation module																																	
CLS-CLASS	218		Information	MIF/UCI - Media interface																																	
CLS-CLASS	218		Information	ICI - InCar Internet																																	
CLS-CLASS	218		Information	IC - Instrument cluster			V																														
CLS-CLASS	218		Information	DVD player																																	
CLS-CLASS	218		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	218		Information	D-FOR - Display in right rear passenger																																	
CLS-CLASS	218		Information	D-FOL - Display in left rear passenger																																	
CLS-CLASS	218		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	218		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	218		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLS-CLASS	218		Information	AUDIO/COMAND	V																																

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
CLS-CLASS	218		Seat/Door	PSD/MSC - Sliding roof control																																	
CLS-CLASS	218		Seat/Door	HKS - Tailgate control																											V	V				V	
CLS-CLASS	218		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	218		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	218		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	218		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	218		Seat/Door	DCM-RL - Door control module rear left																																	
CLS-CLASS	218		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	218		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	218		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	218		Air Conditioning	AAC - Automatic air conditioning														V								V											
CL-CLASS	215		Drive	ME/CDI/CNG - Engine control unit																																	
CL-CLASS	215		Drive	ETC - Electronic transmission control																																	
CL-CLASS	215		Drive	ESM - Electronic selector module																																	
CL-CLASS	215		Drive	DTR - Distronic																																	
CL-CLASS	215		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	215		Chassis	Suspension																																	
CL-CLASS	215		Chassis	PSE - Pneumatic system equipment																																	
CL-CLASS	215		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	215		Body	UCP - Upper control panel																																	
CL-CLASS	215		Body	System diagnosis																																	
CL-CLASS	215		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	215		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	215		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CL-CLASS	215		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	215		Body	RCM - Rear control module																																	
CL-CLASS	215		Body	OCP - Overhead control panel																																	
CL-CLASS	215		Body	Multifunction control unit																																	
CL-CLASS	215		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	215		Body	HSW/LRH - Steering wheel heater																																	
CL-CLASS	215		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	215		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	215		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	215		Body	CGW - Central gateway																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
CL-CLASS	215		Body	AHE - Trailer recognition																																	
CL-CLASS	215		Body	AB - Airbag																																	
CL-CLASS	215		Information	TV - TV tuner																																	
CL-CLASS	215		Information	PTS - Parktronic system																																	
CL-CLASS	215		Information	NAV - Navigation module																																	
CL-CLASS	215		Information	IC - Instrument cluster					V			V																									
CL-CLASS	215		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	215		Information	AUDIO/COMAND																																	
CL-CLASS	215		Information	AGW - Audio gateway																																	
CL-CLASS	215		Seat/Door	OSB-FR - Multicontour backrest front right																																	
CL-CLASS	215		Seat/Door	OSB-FL - Multicontour backrest front left																																	
CL-CLASS	215		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	215		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	215		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	215		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	215		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	215		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
CL-CLASS	215		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	216		Drive	ME/CDI/CNG - Engine control unit															V	V			V	V		V		V		V					V		
CL-CLASS	216		Drive	ETC - Electronic transmission control																																	
CL-CLASS	216		Drive	ISM - Intelligent servo module																																	
CL-CLASS	216		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	216		Drive	DTR - Distronic																																	
CL-CLASS	216		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	216		Chassis	Suspension																																	
CL-CLASS	216		Chassis	ES - Electrical power steering																																	
CL-CLASS	216		Chassis	EFB - Electric parking brake																																	
CL-CLASS	216		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	216		Body	WSS - Weight sensing system																																	
CL-CLASS	216		Body	UCP - Upper control panel																																	
CL-CLASS	216		Body	System diagnosis																																	
CL-CLASS	216		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	216		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	216		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	216		Body	RCM - Rear control module																																	
CL-CLASS	216		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
CL-CLASS	216		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	216		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	216		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	216		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	216		Body	CGW - Central gateway																																	
CL-CLASS	216		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	216		Body	AHE - Trailer recognition																																	
CL-CLASS	216		Body	AB - Airbag																																	
CL-CLASS	216		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	216		Information	VCS - Voice control																																	
CL-CLASS	216		Information	TV - TV tuner																																	
CL-CLASS	216		Information	Tuner - Standard tuner																																	
CL-CLASS	216		Information	SGR - Radar sensors control unit																																	
CL-CLASS	216		Information	MFK - Multifunction camera																																	
CL-CLASS	216		Information	RFK - Backup camera											V																						
CL-CLASS	216		Information	PTS - Parktronic system																																	
CL-CLASS	216		Information	NSA - Night View Assist																																	
CL-CLASS	216		Information	NBR-LF - Left front range radar																																	
CL-CLASS	216		Information	NAV - Navigation module																																	
CL-CLASS	216		Information	MIF/UCI - Media interface																																	
CL-CLASS	216		Information	ICI - InCar Internet																																	
CL-CLASS	216		Information	IC - Instrument cluster																																	
CL-CLASS	216		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	216		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	216		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	216		Information	AUDIO/COMAND	V																																
CL-CLASS	216		Information	ASSYST PLUS - PLUS Active Service System																																	
CL-CLASS	216		Information	ASSYST Active Service System																																	
CL-CLASS	216		Seat/Door	TLC/GTO - Garage door opener																																	
CL-CLASS	216		Seat/Door	HKS - Tailgate control																										V	V				V	
CL-CLASS	216		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	216		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	216		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	216		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
CL-CLASS	216		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	216		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	216		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	217		Drive	SCR - Selective catalytic reduction																																	
CL-CLASS	217		Drive	SG-EM - Power electronics																																	
CL-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	217		Drive	DTR - Distronic																																	
CL-CLASS	217		Drive	ISM - Intelligent servo module																																	
CL-CLASS	217		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
CL-CLASS	217		Drive	ETC - Electronic transmission control												V																	V			
CL-CLASS	217		Drive	PTCU - Common powertrain controller																																	
CL-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	217		Chassis	ABS/ESP - Electronic stability program																	V	V			V												
CL-CLASS	217		Chassis	ES - Electrical power steering																																	
CL-CLASS	217		Chassis	Suspension																																	
CL-CLASS	217		Chassis	EFB - Electric parking brake																																	
CL-CLASS	217		Information	TPAD - Touchpad																																	
CL-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	217		Information	360' - Camera																																	
CL-CLASS	217		Information	SOUND - Sound system																																	
CL-CLASS	217		Information	RFK - Backup camera																																	
CL-CLASS	217		Information	SGR - Radar sensors control unit																																	
CL-CLASS	217		Information	PTS - Parktronic system																																	
CL-CLASS	217		Information	NSA - Night View Assist																																	
CL-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CL-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CL-CLASS	217		Information	NBR-RF - Right front range radar																																	
CL-CLASS	217		Information	NBR-LF - Left front range radar																																	
CL-CLASS	217		Information	MFK - Multifunction camera																																	
CL-CLASS	217		Information	Head-up display																																	
CL-CLASS	217		Information	AUDIO/COMAND																																	
CL-CLASS	217		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	217		Information	KAB - Camera cover																																	
CL-CLASS	217		Information	IC - Instrument cluster			V																														
CL-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
CL-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CL-CLASS	217		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	AB - Airbag																																	
CL-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
CL-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	217		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	217		Seat/Door	HKS - Tailgate control																																	V
CL-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
CL-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
CL-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																						V											
SLK-CLASS	170		Drive	ME/CDI/CNG - Engine control unit		V																															
SLK-CLASS	170		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	170		Drive	ESM - Electronic selector module																																	
SLK-CLASS	170		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	170		Chassis	VP - Vacuum pump brake booster																																	
SLK-CLASS	170		Chassis	BAS - Brake assist																																	
SLK-CLASS	170		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	170		Body	AB - Airbag																																	
SLK-CLASS	170		Information	IC - Instrument cluster					V			V																									
SLK-CLASS	170		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	170		Information	AUDIO/COMAND																																	
SLK-CLASS	170		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
SLK-CLASS	170		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	171		Drive	ME/CDI/CNG - Engine control unit		V																		V													
SLK-CLASS	171		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	171		Drive	ESM - Electronic selector module																																	
SLK-CLASS	171		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	171		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	171		Body	WSS - Weight sensing system																																	
SLK-CLASS	171		Body	UCP - Upper control panel																																	
SLK-CLASS	171		Body	System diagnosis																																	
SLK-CLASS	171		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	171		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	171		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLK-CLASS	171		Body	OCP - Overhead control panel																																	
SLK-CLASS	171		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	171		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	171		Body	CGW - Central gateway																																	
SLK-CLASS	171		Body	AB - Airbag																																	
SLK-CLASS	171		Information	TV - TV tuner																																	
SLK-CLASS	171		Information	SOUND - Sound system																																	
SLK-CLASS	171		Information	PTS - Parktronic system																																	
SLK-CLASS	171		Information	MIF/UCI - Media interface																																	
SLK-CLASS	171		Information	IC - Instrument cluster																																	
SLK-CLASS	171		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	171		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	171		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SLK-CLASS	171		Information	AUDIO/COMAND																																	
SLK-CLASS	171		Information	ASSYST PLUS - PLUS Active Service System																																	
SLK-CLASS	171		Information	ASSYST Active Service System																																	
SLK-CLASS	171		Information	AGW - Audio gateway																																	
SLK-CLASS	171		Seat/Door	RVC/VDS - Convertible roof control																																	
SLK-CLASS	171		Seat/Door	HS - Seat heater																																	
SLK-CLASS	171		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	171		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	171		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	171		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	171		Air Conditioning	AAC - Automatic air conditioning																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
SLK-CLASS	172		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
SLK-CLASS	172		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	172		Drive	ESM - Electronic selector module																																	
SLK-CLASS	172		Drive	DTR - Distronic																																	
SLK-CLASS	172		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLK-CLASS	172		Chassis	ABS/ESP - Electronic stability program																																	
SLK-CLASS	172		Chassis	Suspension																																	
SLK-CLASS	172		Chassis	ES - Electrical power steering																																	
SLK-CLASS	172		Chassis	EFB - Electric parking brake																																	
SLK-CLASS	172		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	172		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	172		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	172		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLK-CLASS	172		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	172		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLK-CLASS	172		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	172		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	172		Body	CGW - Central gateway																																	
SLK-CLASS	172		Body	AB - Airbag																																	
SLK-CLASS	172		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SLK-CLASS	172		Information	ZAN - Audio/COMAND display																																	
SLK-CLASS	172		Information	TV - TV tuner																																	
SLK-CLASS	172		Information	SOUND - Sound system																																	
SLK-CLASS	172		Information	SGR - Radar sensors control unit																																	
SLK-CLASS	172		Information	MFK - Multifunction camera																																	
SLK-CLASS	172		Information	PTS - Parktronic system																																	
SLK-CLASS	172		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLK-CLASS	172		Information	NBR-RF - Right front range radar																																	
SLK-CLASS	172		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLK-CLASS	172		Information	NBR-LF - Left front range radar																																	
SLK-CLASS	172		Information	NAV - Navigation module																																	
SLK-CLASS	172		Information	MIF/UCI - Media interface																																	
SLK-CLASS	172		Information	IC - Instrument cluster			V																														
SLK-CLASS	172		Information	DTA - Mbrace or TELEAID/GPS Box																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
SLK-CLASS	172		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	172		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLK-CLASS	172		Information	AUDIO/COMAND	V																																
SLK-CLASS	172		Seat/Door	RVC/VDS - Convertible roof control																																	
SLK-CLASS	172		Seat/Door	PSD/MSC - Sliding roof control																																	
SLK-CLASS	172		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	172		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	172		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	172		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	172		Air Conditioning	AAC - Automatic air conditioning														V								V											
SL-CLASS	129		Drive	ME/CDI/CNG - Engine control unit																																	
SL-CLASS	129		Drive	ETC - Electronic transmission control																																	
SL-CLASS	129		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	129		Chassis	BAS - Brake assist																																	
SL-CLASS	129		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	129		Body	AB - Airbag																																	
SL-CLASS	129		Information	NAV - Navigation module																																	
SL-CLASS	129		Information	IC - Instrument cluster					V			V																									
SL-CLASS	129		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	129		Information	AUDIO/COMAND																																	
SL-CLASS	129		Information	APS - Auto pilot system																																	
SL-CLASS	129		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	129		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	230		Drive	ME/CDI/CNG - Engine control unit																				V													
SL-CLASS	230		Drive	ETC - Electronic transmission control																																	
SL-CLASS	230		Drive	ESM - Electronic selector module																																	
SL-CLASS	230		Drive	DTR - Distronic																																	
SL-CLASS	230		Drive	AMG DRIVE UNIT																																	
SL-CLASS	230		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	230		Chassis	Suspension																																	
SL-CLASS	230		Chassis	SBC - Sensotronic Brake Control																																	
SL-CLASS	230		Chassis	PSE - Pneumatic system equipment																																	
SL-CLASS	230		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	230		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	230		Body	WSS - Weight sensing system																																	
SL-CLASS	230		Body	System diagnosis																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
SL-CLASS	230		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	230		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	230		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SL-CLASS	230		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	230		Body	OCP - Overhead control panel																																	
SL-CLASS	230		Body	LCP/HBF - Lower/Rear control panel																																	
SL-CLASS	230		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	230		Body	HSW/LRH - Steering wheel heater																																	
SL-CLASS	230		Body	Headlamp-R - Headlamp control unit																																	
SL-CLASS	230		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	230		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	230		Body	CGW - Central gateway																																	
SL-CLASS	230		Body	BNS/BMS - Battery sensor																																	
SL-CLASS	230		Body	AB - Airbag																																	
SL-CLASS	230		Information	TV - TV tuner																																	
SL-CLASS	230		Information	SOUND - Sound system																																	
SL-CLASS	230		Information	PTS - Parktronic system																																	
SL-CLASS	230		Information	MIF/UCI - Media interface																																	
SL-CLASS	230		Information	IC - Instrument cluster																																	
SL-CLASS	230		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	230		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	230		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SL-CLASS	230		Information	AUDIO/COMAND																																	
SL-CLASS	230		Information	AGW - Audio gateway																																	
SL-CLASS	230		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	230		Seat/Door	OSB-FR - Multicontour backrest front right																																	
SL-CLASS	230		Seat/Door	OSB-FL - Multicontour backrest front left																																	
SL-CLASS	230		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	230		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	230		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	230		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	230		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	230		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	231		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
SL-CLASS	231		Drive	ETC - Electronic transmission control												V																	V				
SL-CLASS	231		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
SL-CLASS	231		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SL-CLASS	231		Drive	DTR - Distronic																																	
SL-CLASS	231		Drive	DSI - Direct select interface																																	
SL-CLASS	231		Drive	AMG DRIVE UNIT																																	
SL-CLASS	231		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	231		Chassis	Suspension																																	
SL-CLASS	231		Chassis	ES - Electrical power steering																																	
SL-CLASS	231		Chassis	EFB - Electric parking brake																																	
SL-CLASS	231		Chassis	FWGW - Chassis gateway																																	
SL-CLASS	231		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	231		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	231		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	231		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	231		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	231		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	231		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	231		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	231		Body	CGW - Central gateway																																	
SL-CLASS	231		Body	AB - Airbag																																	
SL-CLASS	231		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SL-CLASS	231		Information	ZAN - Audio/COMAND display																																	
SL-CLASS	231		Information	TV - TV tuner																																	
SL-CLASS	231		Information	SOUND - Sound system																																	
SL-CLASS	231		Information	SGR - Radar sensors control unit																																	
SL-CLASS	231		Information	RFK - Backup camera																																	
SL-CLASS	231		Information	MFK - Multifunction camera																																	
SL-CLASS	231		Information	PTS - Parktronic system																																	
SL-CLASS	231		Information	NSA - Night View Assist																																	
SL-CLASS	231		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SL-CLASS	231		Information	NBR-RF - Right front range radar																																	
SL-CLASS	231		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SL-CLASS	231		Information	NBR-LF - Left front range radar																																	
SL-CLASS	231		Information	MIF/UCI - Media interface																																	
SL-CLASS	231		Information	IC - Instrument cluster			V																														

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
SL-CLASS	231		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	231		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	231		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SL-CLASS	231		Information	AUDIO/COMAND	V																																
SL-CLASS	231		Information	AMG Performance Media																																	
SL-CLASS	231		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	231		Seat/Door	PSD/MSC - Sliding roof control																																	
SL-CLASS	231		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	231		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	231		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
SL-CLASS	231		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	231		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	231		Air Conditioning	AAC - Automatic air conditioning														V								V											
SLS-CLASS	197		Drive	PTCU - Common powertrain controller																																	
SLS-CLASS	197		Drive	ME/CDI/CNG - Engine control unit																				V													
SLS-CLASS	197		Drive	ETC - Electronic transmission control												V																		V			
SLS-CLASS	197		Drive	ISM - Intelligent servo module																																	
SLS-CLASS	197		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLS-CLASS	197		Drive	DSI - Direct select interface																																	
SLS-CLASS	197		Drive	AMG DRIVE UNIT																																	
SLS-CLASS	197		Chassis	ABS/ESP - Electronic stability program																																	
SLS-CLASS	197		Chassis	Suspension																																	
SLS-CLASS	197		Chassis	ES - Electrical power steering																																	
SLS-CLASS	197		Chassis	EFB - Electric parking brake																																	
SLS-CLASS	197		Chassis	TPM - Tire pressure monitor																																	
SLS-CLASS	197		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	CSHV - Crash sensor/high-voltage battery																																	
SLS-CLASS	197		Body	BNS/BMS - Battery sensor															V	V			V			V		V		V					V		
SLS-CLASS	197		Body	WSS - Weight sensing system																																	
SLS-CLASS	197		Body	SCM [MRM] - Steering column module																																	
SLS-CLASS	197		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLS-CLASS	197		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLS-CLASS	197		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
SLS-CLASS	197		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLS-CLASS	197		Body	EZS/EIS - Electronic ignition lock																																	
SLS-CLASS	197		Body	CGW - Central gateway																																	
SLS-CLASS	197		Body	AB - Airbag																																	
SLS-CLASS	197		Information	MFK - Multifunction camera																																	
SLS-CLASS	197		Information	SGR - Radar sensors control unit																																	
SLS-CLASS	197		Information	ZAN - Audio/COMAND display																																	
SLS-CLASS	197		Information	SOUND - Sound system																																	
SLS-CLASS	197		Information	PTS - Parktronic system																																	
SLS-CLASS	197		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLS-CLASS	197		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLS-CLASS	197		Information	MIF/UCI - Media interface																																	
SLS-CLASS	197		Information	IC - Instrument cluster			V																														
SLS-CLASS	197		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLS-CLASS	197		Information	DAB/SDAR - Digital/Satellite radio																																	
SLS-CLASS	197		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLS-CLASS	197		Information	AUDIO/COMAND	V																																
SLS-CLASS	197		Information	AMG Performance Media																																	
SLS-CLASS	197		Seat/Door	RVC/VDS - Convertible roof control																																	
SLS-CLASS	197		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLS-CLASS	197		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLS-CLASS	197		Seat/Door	DCM-FR - Door control module front right																																	
SLS-CLASS	197		Seat/Door	DCM-FL - Door control module front left																																	
SLS-CLASS	197		Air Conditioning	AAC - Automatic air conditioning														V								V											
AMG GT	190		Drive	DTR - Distronic																																	
AMG GT	190		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
AMG GT	190		Drive	DSI - Direct select interface																																	
AMG GT	190		Drive	AMG DRIVE UNIT																																	
AMG GT	190		Drive	PTCU - Common powertrain controller																																	
AMG GT	190		Drive	ME/CDI/CNG - Engine control unit															V	V			V			V		V		V					V		
AMG GT	190		Drive	ETC - Electronic transmission control												V																	V			
AMG GT	190		Chassis	TPM - Tire pressure monitor																																	
AMG GT	190		Chassis	Suspension																																	
AMG GT	190		Chassis	ABS/ESP - Electronic stability program																																	
AMG GT	190		Chassis	EFB - Electric parking brake																																	
AMG GT	190		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
AMG GT	190		Information	DAB/SDAR - Digital/Satellite radio																																	
AMG GT	190		Information	SOUND - Sound system																																	
AMG GT	190		Information	RFK - Backup camera																																	
AMG GT	190		Information	PTS - Parktronic system																																	
AMG GT	190		Information	MFK - Multifunction camera																																	
AMG GT	190		Information	IC - Instrument cluster			V																														
AMG GT	190		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
AMG GT	190		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
AMG GT	190		Information	AUDIO/COMAND																																	
AMG GT	190		Information	ZAN - Audio/COMAND display																																	
AMG GT	190		Information	COU [ZBE] - Audio/COMAND operating unit																																	
AMG GT	190		Information	DTA - Mbrace or TELEAID/GPS Box																																	
AMG GT	190		Information	AMG Performance Media																																	
AMG GT	190		Body	SCM [MRM] - Steering column module																																	
AMG GT	190		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
AMG GT	190		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
AMG GT	190		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
AMG GT	190		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
AMG GT	190		Body	AB - Airbag																																	
AMG GT	190		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
AMG GT	190		Body	Headlamp-R - Headlamp control unit																																	
AMG GT	190		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
AMG GT	190		Body	SG-AWF - Collision prevention assist																																	
AMG GT	190		Body	EZS/EIS - Electronic ignition lock																																	
AMG GT	190		Body	CGW - Central gateway																																	
AMG GT	190		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
AMG GT	190		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
AMG GT	190		Seat/Door	DCM-FR - Door control module front right																																	
AMG GT	190		Seat/Door	DCM-FL - Door control module front left																																	
AMG GT	190		Air Conditioning	AAC - Automatic air conditioning														V								V											
SLR-CLASS	199		Drive	ME/CDI/CNG - Engine control unit																																	
SLR-CLASS	199		Drive	ETC - Electronic transmission control																																	
SLR-CLASS	199		Drive	ESM - Electronic selector module																																	
SLR-CLASS	199		Chassis	ABS/ESP - Electronic stability program																																	
SLR-CLASS	199		Chassis	SBC - Sensotronic Brake Control																																	
SLR-CLASS	199		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
SLR-CLASS	199		Body	WSS - Weight sensing system																																	
SLR-CLASS	199		Body	SCM [MRM] - Steering column module																																	
SLR-CLASS	199		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLR-CLASS	199		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SLR-CLASS	199		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLR-CLASS	199		Body	OCP - Overhead control panel																																	
SLR-CLASS	199		Body	LCP/HBF - Lower/Rear control panel																																	
SLR-CLASS	199		Body	Headlamp-R - Headlamp control unit																																	
SLR-CLASS	199		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLR-CLASS	199		Body	EZS/EIS - Electronic ignition lock																																	
SLR-CLASS	199		Body	CGW - Central gateway																																	
SLR-CLASS	199		Body	BNS/BMS - Battery sensor																																	
SLR-CLASS	199		Body	AB - Airbag																																	
SLR-CLASS	199		Information	IC - Instrument cluster																																	
SLR-CLASS	199		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLR-CLASS	199		Information	AUDIO/COMAND																																	
SLR-CLASS	199		Seat/Door	DCM-FR - Door control module front right																																	
SLR-CLASS	199		Seat/Door	DCM-FL - Door control module front left																																	
SLR-CLASS	199		Air Conditioning	AAC - Automatic air conditioning																																	
MAYBACH	240		Drive	ME/CDI/CNG - Engine control unit																				V													
MAYBACH	240		Drive	ETC - Electronic transmission control																																	
MAYBACH	240		Drive	ESM - Electronic selector module																																	
MAYBACH	240		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
MAYBACH	240		Drive	DTR - Distronic	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
MAYBACH	240		Chassis	ABS/ESP - Electronic stability program																																	
MAYBACH	240		Chassis	Suspension																																	
MAYBACH	240		Chassis	SBC - Sensotronic Brake Control																																	
MAYBACH	240		Chassis	TPM - Tire pressure monitor																																	
MAYBACH	240		Body	WSS - Weight sensing system																																	
MAYBACH	240		Body	System diagnosis																																	
MAYBACH	240		Body	SCM [MRM] - Steering column module																																	
MAYBACH	240		Body	HSW/LRH - Steering wheel heater																																	
MAYBACH	240		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
MAYBACH	240		Body	AB - Airbag																																	
MAYBACH	240		Information	TV - TV tuner																																	
MAYBACH	240		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
MAYBACH	240		Information	DTA - Mbrace or TELEAID/GPS Box																																	
MAYBACH	240		Information	AGW - Audio gateway																																	
MAYBACH	240		Seat/Door	REDC/RWT - Rear end door control module																																	
MAYBACH	240		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All_Model(BETA)	16P Connector		Drive	SG-EM - Power electronics																																	
All_Model(BETA)	16P Connector		Drive	HFPM - Haptic accelerator pedal module																																	
All_Model(BETA)	16P Connector		Drive	ME/CDI/CNG - Engine control unit		V												V	V			V	V		V		V		V					V			
All_Model(BETA)	16P Connector		Drive	ETC - Electronic transmission control												V																	V				
All_Model(BETA)	16P Connector		Drive	ESM - Electronic selector module																																	
All_Model(BETA)	16P Connector		Drive	VG - Transfer case																																	
All_Model(BETA)	16P Connector		Drive	VECU - Power monitoring control unit																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-B - Electric motor control unit B																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-A - Electric motor control unit A																																	
All_Model(BETA)	16P Connector		Drive	SCR - Selective catalytic reduction																																	
All_Model(BETA)	16P Connector		Drive	PTCU - Common powertrain controller																																	
All_Model(BETA)	16P Connector		Drive	Natural gas control unit																																	
All_Model(BETA)	16P Connector		Drive	ISM - Intelligent servo module																																	
All_Model(BETA)	16P Connector		Drive	Hydrogen tank control unit																																	
All_Model(BETA)	16P Connector		Drive	HSG - Hybrid control unit																	V	V			V												
All_Model(BETA)	16P Connector		Drive	High-temperature coolant pump control unit																																	
All_Model(BETA)	16P Connector		Drive	Fuel cell control unit																																	
All_Model(BETA)	16P Connector		Drive	FSCU-R - Control unit fuel pump																																	
All_Model(BETA)	16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
All_Model(BETA)	16P Connector		Drive	EMPI - Electronic Motor Pump Inverter																																	
All_Model(BETA)	16P Connector		Drive	Electric drive control unit																																	
All_Model(BETA)	16P Connector		Drive	DTR - Distronic																																	
All_Model(BETA)	16P Connector		Drive	DSI - Direct select interface																																	
All_Model(BETA)	16P Connector		Drive	Compressed Natural Gas Control Module																																	
All_Model(BETA)	16P Connector		Drive	CC - Cruise control																																	
All_Model(BETA)	16P Connector		Drive	BSA - Belt-driven starter/alternator																																	
All_Model(BETA)	16P Connector		Drive	AMG DRIVE UNIT																																	
All_Model(BETA)	16P Connector		Drive	ACS - Automatic clutch system																																	
All_Model(BETA)	16P Connector		Chassis	ABS/ESP - Electronic stability program																																	
All_Model(BETA)	16P Connector		Chassis	Suspension																																	
All_Model(BETA)	16P Connector		Chassis	SBC - Sensotronic Brake Control																																	
All_Model(BETA)	16P Connector		Chassis	PSE - Pneumatic system equipment																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
All_Model(BETA)	16P Connector		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
All_Model(BETA)	16P Connector		Chassis	HAQ - Interwheel differential lock at rear axle																																	
All_Model(BETA)	16P Connector		Chassis	FWGW - Chassis gateway																																	
All_Model(BETA)	16P Connector		Chassis	ES - Electrical power steering																																	
All_Model(BETA)	16P Connector		Chassis	EFB - Electric parking brake																																	
All_Model(BETA)	16P Connector		Chassis	BAS - Brake assist																																	
All_Model(BETA)	16P Connector		Chassis	VP - Vacuum pump brake booster																																	
All_Model(BETA)	16P Connector		Chassis	TPM - Tire pressure monitor																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
All_Model(BETA)	16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
All_Model(BETA)	16P Connector		Body	CSHV - Crash sensor/high-voltage battery																																	
All_Model(BETA)	16P Connector		Body	WSS - Weight sensing system																																	
All_Model(BETA)	16P Connector		Body	UCP - Upper control panel																																	
All_Model(BETA)	16P Connector		Body	System diagnosis																																	
All_Model(BETA)	16P Connector		Body	SG-DDW - DC/DC converter control unit																																	
All_Model(BETA)	16P Connector		Body	SG-AWF - Collision prevention assist																																	
All_Model(BETA)	16P Connector		Body	SCM [MRM] - Steering column module																																	
All_Model(BETA)	16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
All_Model(BETA)	16P Connector		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
All_Model(BETA)	16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
All_Model(BETA)	16P Connector		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
All_Model(BETA)	16P Connector		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
All_Model(BETA)	16P Connector		Body	RCM - Rear control module						V	V																										
All_Model(BETA)	16P Connector		Body	OCP - Overhead control panel																																	
All_Model(BETA)	16P Connector		Body	Multifunction control unit																																	
All_Model(BETA)	16P Connector		Body	LCP/HBF - Lower/Rear control panel																																	
All_Model(BETA)	16P Connector		Body	LAE [LAA] - Loading floor automatically extendable																																	
All_Model(BETA)	16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
All_Model(BETA)	16P Connector		Body	HSW/LRH - Steering wheel heater																																	
All_Model(BETA)	16P Connector		Body	Headlamp-R - Headlamp control unit																																	
All_Model(BETA)	16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
All_Model(BETA)	16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
All_Model(BETA)	16P Connector		Body	CGW - Central gateway																																	
All_Model(BETA)	16P Connector		Body	BNS/BMS - Battery sensor																																	
All_Model(BETA)	16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
All_Model(BETA)	16P Connector		Body	AHE - Trailer recognition																																	
All_Model(BETA)	16P Connector		Body	AB - Airbag																																	
All_Model(BETA)	16P Connector		Body	AAM - All activity module																																	
All_Model(BETA)	16P Connector		Information	TPAD - Touchpad																																	
All_Model(BETA)	16P Connector		Information	Head-up display																																	
All_Model(BETA)	16P Connector		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
All_Model(BETA)	16P Connector		Information	KAB - Camera cover																																	
All_Model(BETA)	16P Connector		Information	ZAN - Audio/COMAND display																																	
All_Model(BETA)	16P Connector		Information	VCS - Voice control																																	
All_Model(BETA)	16P Connector		Information	TV - TV tuner																																	
All_Model(BETA)	16P Connector		Information	Tuner - Standard tuner																																	
All_Model(BETA)	16P Connector		Information	Sound generator for exhaust system																																	
All_Model(BETA)	16P Connector		Information	SOUND - Sound system																																	
All_Model(BETA)	16P Connector		Information	SGR - Radar sensors control unit																																	
All_Model(BETA)	16P Connector		Information	360' - Camera																																	
All_Model(BETA)	16P Connector		Information	MFK - Multifunction camera																																	
All_Model(BETA)	16P Connector		Information	RFK - Backup camera											V																						
All_Model(BETA)	16P Connector		Information	PTS - Parktronic system																																	
All_Model(BETA)	16P Connector		Information	NSA - Night View Assist																																	
All_Model(BETA)	16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-RF - Right front range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
All_Model(BETA)	16P Connector		Information	NBR-LF - Left front range radar																																	
All_Model(BETA)	16P Connector		Information	NAV - Navigation module																																	
All_Model(BETA)	16P Connector		Information	MIF/UCI - Media interface																																	
All_Model(BETA)	16P Connector		Information	ICI - InCar Internet																																	
All_Model(BETA)	16P Connector		Information	IC - Instrument cluster			V		V			V																									
All_Model(BETA)	16P Connector		Information	DVD player																																	
All_Model(BETA)	16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																	
All_Model(BETA)	16P Connector		Information	D-FOR - Display in right rear passenger																																	
All_Model(BETA)	16P Connector		Information	D-FOL - Display in left rear passenger																																	
All_Model(BETA)	16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
All_Model(BETA)	16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
All_Model(BETA)	16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
All_Model(BETA)	16P Connector		Information	CM - Compass module																																	
All_Model(BETA)	16P Connector		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Self-test	Sensor rotor adaptation	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit
All Model(BETA)	16P Connector		Information	AUDIO/COMAND	V																																
All Model(BETA)	16P Connector		Information	ASSYST PLUS - PLUS Active Service System																																	
All Model(BETA)	16P Connector		Information	ASSYST Active Service System																																	
All Model(BETA)	16P Connector		Information	APS - Auto pilot system																																	
All Model(BETA)	16P Connector		Information	AMG Performance Media																																	
All Model(BETA)	16P Connector		Information	AGW - Audio gateway																																	
All Model(BETA)	16P Connector		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-MR - Right center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-ML - Left center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TLC/GTO - Garage door opener																																	
All Model(BETA)	16P Connector		Seat/Door	RVC/VDS - Convertible roof control																																	
All Model(BETA)	16P Connector		Seat/Door	REDC/RWT - Rear end door control module																																	
All Model(BETA)	16P Connector		Seat/Door	PSD/MSC - Sliding roof control																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-R - Multicontour backrest rear																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FR - Multicontour backrest front right																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FL - Multicontour backrest front left																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	HS - Seat heater																																	
All Model(BETA)	16P Connector		Seat/Door	HKS - Tailgate control																										V	V			V	V
All Model(BETA)	16P Connector		Seat/Door	ESA-R - Electric seat adjustment rear																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
All Model(BETA)	16P Connector		Seat/Door	ERA - Electric fold down backrest system																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-RR - Door control module rear right																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-RL - Door control module rear left																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-FR - Door control module front right																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-FL - Door control module front left																																	
All Model(BETA)	16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All Model(BETA)	16P Connector		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
All Model(BETA)	16P Connector		Air Conditioning	HBF - Rear control panel																																	
All Model(BETA)	16P Connector		Air Conditioning	HB - Heater booster																																	
All Model(BETA)	16P Connector		Air Conditioning	EKMK - Electric refrigerant compressor																																	
All Model(BETA)	16P Connector		Air Conditioning	AAC - Automatic air conditioning														V								V											

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
A-CLASS	68		Drive	ME/CDI/CNG - Engine control unit																																	
A-CLASS	68		Drive	ETC - Electronic transmission control																																	
A-CLASS	68		Drive	ESM - Electronic selector module																																	
A-CLASS	68		Drive	ACS - Automatic clutch system																																	
A-CLASS	68		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Chassis	ABS/ESP - Electronic stability program																																	
A-CLASS	168		Body	LCP/HBF - Lower/Rear control panel																																	
A-CLASS	168		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	168		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	168		Body	AB - Airbag																																	
A-CLASS	168		Information	PTS - Parktronic system																																	
A-CLASS	168		Information	IC - Instrument cluster																																	
A-CLASS	168		Information	AUDIO/COMAND																																	
A-CLASS	168		Information	APS - Auto pilot system																																	
A-CLASS	168		Seat/Door	DCM-RR - Door control module rear right																																	
A-CLASS	168		Seat/Door	DCM-RL - Door control module rear left																																	
A-CLASS	168		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	168		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	168		Air Conditioning	TSTH/STH - Stationary heater with remote control																														V		V
A-CLASS	168		Air Conditioning	HB - Heater booster																														V		V
A-CLASS	168		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	169		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V						V										
A-CLASS	169		Drive	ETC - Electronic transmission control																																	
A-CLASS	169		Drive	ESM - Electronic selector module																																	
A-CLASS	169		Drive	BSA - Belt-driven starter/alternator																																	
A-CLASS	169		Chassis	ABS/ESP - Electronic stability program																									V	V							
A-CLASS	169		Chassis	ES - Electrical power steering																																	
A-CLASS	169		Body	SCM [MRM] - Steering column module																																	
A-CLASS	169		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
A-CLASS	169		Body	OCP - Overhead control panel																								V									
A-CLASS	169		Body	Multifunction control unit																																	
A-CLASS	169		Body	Headlamp-R - Headlamp control unit																																	
A-CLASS	169		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
A-CLASS	169		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	169		Body	CGW - Central gateway																																	
A-CLASS	169		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
A-CLASS	169		Body	AHE - Trailer recognition																																	
A-CLASS	169		Body	AB - Airbag																																	
A-CLASS	169		Information	SOUND - Sound system																																	
A-CLASS	169		Information	PTS - Parktronic system																																	
A-CLASS	169		Information	MIF/UCI - Media interface																																	
A-CLASS	169		Information	IC - Instrument cluster																																	
A-CLASS	169		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	169		Information	CTEL/TEL - Cellular/Mobile telephone																																	
A-CLASS	169		Information	AUDIO/COMAND																																	
A-CLASS	169		Information	ASSYST PLUS - PLUS Active Service System																																	
A-CLASS	169		Information	ASSYST Active Service System																																	
A-CLASS	169		Information	AGW - Audio gateway																																	
A-CLASS	169		Seat/Door	DCM-RR - Door control module rear right																																	
A-CLASS	169		Seat/Door	DCM-RL - Door control module rear left																																	
A-CLASS	169		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	169		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	169		Air Conditioning	AAC - Automatic air conditioning																																	
A-CLASS	176		Drive	VG - Transfer case																																	
A-CLASS	176		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
A-CLASS	176		Drive	ETC - Electronic transmission control																																	
A-CLASS	176		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
A-CLASS	176		Drive	DTR - Distronic																																	
A-CLASS	176		Drive	DSI - Direct select interface																																	
A-CLASS	176		Drive	PTCU - Common powertrain controller																																	
A-CLASS	176		Chassis	ABS/ESP - Electronic stability program						V																											
A-CLASS	176		Chassis	ES - Electrical power steering																																	
A-CLASS	176		Chassis	EFB - Electric parking brake																																	
A-CLASS	176		Chassis	TPM - Tire pressure monitor																										V							
A-CLASS	176		Body	SG-AWF - Collision prevention assist																																	
A-CLASS	176		Body	SCM [MRM] - Steering column module																																	
A-CLASS	176		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
A-CLASS	176		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
A-CLASS	176		Body	Multifunction control unit																																	
A-CLASS	176		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
A-CLASS	176		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
A-CLASS	176		Body	EZS/EIS - Electronic ignition lock																																	
A-CLASS	176		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
A-CLASS	176		Body	AHE - Trailer recognition																																	
A-CLASS	176		Body	AB - Airbag																																	
A-CLASS	176		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
A-CLASS	176		Information	ZAN - Audio/COMAND display																																	
A-CLASS	176		Information	TV - TV tuner																																	
A-CLASS	176		Information	SOUND - Sound system																																	
A-CLASS	176		Information	RFK - Backup camera																																	
A-CLASS	176		Information	MFK - Multifunction camera																																	
A-CLASS	176		Information	PTS - Parktronic system																																	
A-CLASS	176		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
A-CLASS	176		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
A-CLASS	176		Information	NAV - Navigation module																																	
A-CLASS	176		Information	MIF/UCI - Media interface																																	
A-CLASS	176		Information	IC - Instrument cluster																																	
A-CLASS	176		Information	DTA - Mbrace or TELEAID/GPS Box																																V	
A-CLASS	176		Information	DAB/SDAR - Digital/Satellite radio																																	
A-CLASS	176		Information	COU [ZBE] - Audio/COMAND operating unit																																	
A-CLASS	176		Information	AUDIO/COMAND																					V	V											
A-CLASS	176		Seat/Door	PSD/MSC - Sliding roof control																																	
A-CLASS	176		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
A-CLASS	176		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
A-CLASS	176		Seat/Door	DCM-FR - Door control module front right																																	
A-CLASS	176		Seat/Door	DCM-FL - Door control module front left																																	
A-CLASS	176		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
A-CLASS	176		Air Conditioning	AAC - Automatic air conditioning														V																			
B-CLASS	245		Drive	ME/CDI/CNG - Engine control unit																V							V										
B-CLASS	245		Drive	ETC - Electronic transmission control																																	
B-CLASS	245		Drive	ESM - Electronic selector module																																	
B-CLASS	245		Drive	Hydrogen tank control unit																																	
B-CLASS	245		Drive	High-temperature coolant pump control unit																																	
B-CLASS	245		Drive	Fuel cell control unit																																	
B-CLASS	245		Drive	Electric drive control unit																																	
B-CLASS	245		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	245		Drive	BSA - Belt-driven starter/alternator																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
B-CLASS	245		Drive	VECU - Power monitoring control unit																																	
B-CLASS	245		Chassis	ABS/ESP - Electronic stability program																									V	V							
B-CLASS	245		Chassis	ES - Electrical power steering																																	
B-CLASS	245		Chassis	VP - Vacuum pump brake booster																																	
B-CLASS	245		Chassis	TPM - Tire pressure monitor																																	
B-CLASS	245		Body	WSS - Weight sensing system																																	
B-CLASS	245		Body	SG-DDW - DC/DC converter control unit																																	
B-CLASS	245		Body	SCM [MRM] - Steering column module																																	
B-CLASS	245		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
B-CLASS	245		Body	OCP - Overhead control panel																								V									
B-CLASS	245		Body	Multifunction control unit																																	
B-CLASS	245		Body	Headlamp-R - Headlamp control unit																												V	V				
B-CLASS	245		Body	Headlamp/Headlamp-L - Headlamp control unit																												V	V				
B-CLASS	245		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	245		Body	CGW - Central gateway																																	
B-CLASS	245		Body	BNS/BMS - Battery sensor																																	
B-CLASS	245		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	245		Body	AHE - Trailer recognition																																	
B-CLASS	245		Body	AB - Airbag																																	
B-CLASS	245		Information	SOUND - Sound system																																	
B-CLASS	245		Information	PTS - Parktronic system																																	
B-CLASS	245		Information	NAV - Navigation module																																	
B-CLASS	245		Information	MIF/UCI - Media interface																																	
B-CLASS	245		Information	IC - Instrument cluster																																	
B-CLASS	245		Information	DTA - Mbrace or TELEAID/GPS Box																																	
B-CLASS	245		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	245		Information	CTEL/TEL - Cellular/Mobile telephone																																	
B-CLASS	245		Information	CM - Compass module																																	
B-CLASS	245		Information	AUDIO/COMAND																																	
B-CLASS	245		Information	ASSYST PLUS - PLUS Active Service System																																	
B-CLASS	245		Information	ASSYST Active Service System																																	
B-CLASS	245		Information	AGW - Audio gateway																																	
B-CLASS	245		Seat/Door	DCM-RR - Door control module rear right																																	
B-CLASS	245		Seat/Door	DCM-RL - Door control module rear left																																	
B-CLASS	245		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	245		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
B-CLASS	245		Air Conditioning	EKMK - Electric refrigerant compressor																																	
B-CLASS	245		Air Conditioning	AAC - Automatic air conditioning																																	
B-CLASS	246		Drive	Compressed Natural Gas Control Module																																	
B-CLASS	246		Drive	VG - Transfer case																																	
B-CLASS	246		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
B-CLASS	246		Drive	ETC - Electronic transmission control																																	
B-CLASS	246		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
B-CLASS	246		Drive	DTR - Distronic																																	
B-CLASS	246		Drive	PTCU - Common powertrain controller																																	
B-CLASS	246		Chassis	ABS/ESP - Electronic stability program						V																											
B-CLASS	246		Chassis	ES - Electrical power steering																																	
B-CLASS	246		Chassis	EFB - Electric parking brake																																	
B-CLASS	246		Chassis	TPM - Tire pressure monitor																										V							
B-CLASS	246		Body	BNS/BMS - Battery sensor																																	
B-CLASS	246		Body	SG-AWF - Collision prevention assist																																	
B-CLASS	246		Body	SCM [MRM] - Steering column module																																	
B-CLASS	246		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
B-CLASS	246		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
B-CLASS	246		Body	Multifunction control unit																																	
B-CLASS	246		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
B-CLASS	246		Body	Headlamp-R - Headlamp control unit																																	
B-CLASS	246		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
B-CLASS	246		Body	EZS/EIS - Electronic ignition lock																																	
B-CLASS	246		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
B-CLASS	246		Body	AHE - Trailer recognition																																	
B-CLASS	246		Body	AB - Airbag																																	
B-CLASS	246		Information	Sound generator for exhaust system																																	
B-CLASS	246		Information	Head-up display																																	
B-CLASS	246		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
B-CLASS	246		Information	ZAN - Audio/COMAND display																																	
B-CLASS	246		Information	TV - TV tuner																																	
B-CLASS	246		Information	SOUND - Sound system																																	
B-CLASS	246		Information	RFK - Backup camera																																	
B-CLASS	246		Information	MFK - Multifunction camera																																	
B-CLASS	246		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
B-CLASS	246		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
B-CLASS	246		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
B-CLASS	246		Information	NAV - Navigation module																																	
B-CLASS	246		Information	MIF/UCI - Media interface																																	
B-CLASS	246		Information	IC - Instrument cluster																																	
B-CLASS	246		Information	DTA - Mbrace or TELEAID/GPS Box																																V	
B-CLASS	246		Information	DAB/SDAR - Digital/Satellite radio																																	
B-CLASS	246		Information	COU [ZBE] - Audio/COMAND operating unit																																	
B-CLASS	246		Information	AUDIO/COMAND																					V	V											
B-CLASS	246		Seat/Door	PSD/MSC - Sliding roof control																																	
B-CLASS	246		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
B-CLASS	246		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
B-CLASS	246		Seat/Door	DCM-FR - Door control module front right																																	
B-CLASS	246		Seat/Door	DCM-FL - Door control module front left																																	
B-CLASS	246		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
B-CLASS	246		Air Conditioning	AAC - Automatic air conditioning														V																			
C-CLASS	202		Drive	ME/CDI/CNG - Engine control unit																							V										
C-CLASS	202		Drive	ETC - Electronic transmission control																																	
C-CLASS	202		Drive	ESM - Electronic selector module																																	
C-CLASS	202		Chassis	PSE - Pneumatic system equipment																																	
C-CLASS	202		Chassis	ABS/ESP - Electronic stability program																																	
C-CLASS	202		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	202		Chassis	BAS - Brake assist																																	
C-CLASS	202		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	202		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	202		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	202		Body	OCP - Overhead control panel																													V				
C-CLASS	202		Body	AB - Airbag																																	
C-CLASS	202		Information	PTS - Parktronic system																																	
C-CLASS	202		Information	NAV - Navigation module																																	
C-CLASS	202		Information	IC - Instrument cluster																																	
C-CLASS	202		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	202		Information	AUDIO/COMAND																																	
C-CLASS	202		Information	APS - Auto pilot system																																	
C-CLASS	202		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	202		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
C-CLASS	202		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	202		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	202		Air Conditioning	TSTH/STH - Stationary heater with remote control																														V			V
C-CLASS	202		Air Conditioning	HB - Heater booster																														V			V
C-CLASS	202		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	203		Drive	ME/CDI/CNG - Engine control unit																V		V					V										
C-CLASS	203		Drive	ETC - Electronic transmission control																																	
C-CLASS	203		Drive	ESM - Electronic selector module																																	
C-CLASS	203		Drive	DTR - Distronic																																	
C-CLASS	203		Chassis	ABS/ESP - Electronic stability program																									V	V							
C-CLASS	203		Chassis	VP - Vacuum pump brake booster																																	
C-CLASS	203		Chassis	BAS - Brake assist																																	
C-CLASS	203		Body	WSS - Weight sensing system																																	
C-CLASS	203		Body	UCP - Upper control panel																																	
C-CLASS	203		Body	System diagnosis																																	
C-CLASS	203		Body	SCM [MRM] - Steering column module																																	
C-CLASS	203		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	203		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	203		Body	OCP - Overhead control panel																								V									
C-CLASS	203		Body	Multifunction control unit																																	
C-CLASS	203		Body	LCP/HBF - Lower/Rear control panel																																	
C-CLASS	203		Body	Headlamp-R - Headlamp control unit																												V	V				
C-CLASS	203		Body	Headlamp/Headlamp-L - Headlamp control unit																												V	V				
C-CLASS	203		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	203		Body	CGW - Central gateway																																	
C-CLASS	203		Body	AHE - Trailer recognition																																	
C-CLASS	203		Body	AB - Airbag																																	
C-CLASS	203		Information	TV - TV tuner																																	
C-CLASS	203		Information	SOUND - Sound system																																	
C-CLASS	203		Information	PTS - Parktronic system																																	
C-CLASS	203		Information	NAV - Navigation module																																	
C-CLASS	203		Information	MIF/UCI - Media interface																																	
C-CLASS	203		Information	IC - Instrument cluster																																	
C-CLASS	203		Information	DTA - Mbrace or TELEAID/GPS Box																																	
C-CLASS	203		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	203		Information	CTEL/TEL - Cellular/Mobile telephone																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
C-CLASS	203		Information	AUDIO/COMAND																																	
C-CLASS	203		Information	AGW - Audio gateway																																	
C-CLASS	203		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	203		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	203		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	203		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	203		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	203		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	203		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	203		Air Conditioning	AAC - Automatic air conditioning																																	
C-CLASS	204		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V						V											
C-CLASS	204		Drive	ETC - Electronic transmission control																																	
C-CLASS	204		Drive	ESM - Electronic selector module																																	
C-CLASS	204		Drive	SCR - Selective catalytic reduction																																	
C-CLASS	204		Drive	ISM - Intelligent servo module																																	
C-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
C-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	204		Drive	DTR - Distronic																																	
C-CLASS	204		Drive	AMG DRIVE UNIT																																	
C-CLASS	204		Drive	PTCU - Common powertrain controller																																	
C-CLASS	204		Chassis	ABS/ESP - Electronic stability program						V																		V	V								
C-CLASS	204		Chassis	Suspension																																	
C-CLASS	204		Chassis	ES - Electrical power steering																																	
C-CLASS	204		Chassis	TPM - Tire pressure monitor																										V							
C-CLASS	204		Body	WSS - Weight sensing system																																	
C-CLASS	204		Body	SCM [MRM] - Steering column module																																	
C-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	204		Body	OCP - Overhead control panel																																	
C-CLASS	204		Body	Multifunction control unit																																	
C-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	204		Body	Headlamp-R - Headlamp control unit																											V	V					
C-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																											V	V					
C-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
C-CLASS	204		Body	CGW - Central gateway																																
C-CLASS	204		Body	AHE - Trailer recognition																																
C-CLASS	204		Body	AB - Airbag																																
C-CLASS	204		Information	Head-up display																																
C-CLASS	204		Information	AVE-H - Rear audio video unit																																
C-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																
C-CLASS	204		Information	ZAN - Audio/COMAND display																																
C-CLASS	204		Information	TV - TV tuner																																
C-CLASS	204		Information	Sound generator for exhaust system																																
C-CLASS	204		Information	SOUND - Sound system																																
C-CLASS	204		Information	SGR - Radar sensors control unit																																
C-CLASS	204		Information	360' - Camera																																
C-CLASS	204		Information	MFK - Multifunction camera																																
C-CLASS	204		Information	RFK - Backup camera																																
C-CLASS	204		Information	PTS - Parktronic system																																
C-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																
C-CLASS	204		Information	NBR-RF - Right front range radar																																
C-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																
C-CLASS	204		Information	NBR-LF - Left front range radar																																
C-CLASS	204		Information	NAV - Navigation module																																
C-CLASS	204		Information	MIF/UCI - Media interface																																
C-CLASS	204		Information	ICI - InCar Internet																																
C-CLASS	204		Information	IC - Instrument cluster																																
C-CLASS	204		Information	DVD player																																
C-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																														V		
C-CLASS	204		Information	D-FOR - Display in right rear passenger																																
C-CLASS	204		Information	D-FOL - Display in left rear passenger																																
C-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																
C-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																
C-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																
C-CLASS	204		Information	AUDIO/COMAND																					V	V										
C-CLASS	204		Information	AMG Performance Media																																
C-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																
C-CLASS	204		Seat/Door	HKS - Tailgate control																																
C-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																
C-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
C-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
C-CLASS	204		Air Conditioning	AAC - Automatic air conditioning														V																			
C-CLASS	205		Drive	SCR - Selective catalytic reduction																																	
C-CLASS	205		Drive	SG-EM - Power electronics																																	
C-CLASS	205		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
C-CLASS	205		Drive	HFPM - Haptic accelerator pedal module																																	
C-CLASS	205		Drive	DTR - Distronic																																	
C-CLASS	205		Drive	ISM - Intelligent servo module																																	
C-CLASS	205		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
C-CLASS	205		Drive	ETC - Electronic transmission control																																	
C-CLASS	205		Drive	PTCU - Common powertrain controller																																	
C-CLASS	205		Chassis	TPM - Tire pressure monitor																																	
C-CLASS	205		Chassis	Suspension																																	
C-CLASS	205		Chassis	ABS/ESP - Electronic stability program																	V																
C-CLASS	205		Chassis	ES - Electrical power steering																																	
C-CLASS	205		Chassis	EFB - Electric parking brake																																	
C-CLASS	205		Information	TPAD - Touchpad																																	
C-CLASS	205		Information	DAB/SDAR - Digital/Satellite radio																																	
C-CLASS	205		Information	360' - Camera																																	
C-CLASS	205		Information	Sound generator for exhaust system																																	
C-CLASS	205		Information	SOUND - Sound system																																	
C-CLASS	205		Information	RFK - Backup camera																																	
C-CLASS	205		Information	SGR - Radar sensors control unit																																	
C-CLASS	205		Information	PTS - Parktronic system																																	
C-CLASS	205		Information	NBR-RF - Right front range radar																																	
C-CLASS	205		Information	NBR-LF - Left front range radar																																	
C-CLASS	205		Information	MFK - Multifunction camera																																	
C-CLASS	205		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
C-CLASS	205		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
C-CLASS	205		Information	Head-up display																																	
C-CLASS	205		Information	AUDIO/COMAND																																	
C-CLASS	205		Information	ZAN - Audio/COMAND display																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
C-CLASS	205		Information	COU [ZBE] - Audio/COMAND operating unit																																	
C-CLASS	205		Information	KAB - Camera cover																																	
C-CLASS	205		Information	IC - Instrument cluster																																	
C-CLASS	205		Information	DTA - Mbrace or TELEAID/GPS Box																															V		
C-CLASS	205		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
C-CLASS	205		Body	AHE - Trailer recognition																																	
C-CLASS	205		Body	SCM [MRM] - Steering column module																																	
C-CLASS	205		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
C-CLASS	205		Body	AB - Airbag																																	
C-CLASS	205		Body	Multifunction control unit																																	
C-CLASS	205		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
C-CLASS	205		Body	Headlamp-R - Headlamp control unit																																	
C-CLASS	205		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
C-CLASS	205		Body	SG-AWF - Collision prevention assist																																	
C-CLASS	205		Body	EZS/EIS - Electronic ignition lock																																	
C-CLASS	205		Body	BNS/BMS - Battery sensor																																	
C-CLASS	205		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
C-CLASS	205		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
C-CLASS	205		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
C-CLASS	205		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
C-CLASS	205		Seat/Door	PSD/MSC - Sliding roof control																																	
C-CLASS	205		Seat/Door	HKS - Tailgate control																																	
C-CLASS	205		Seat/Door	DCM-RR - Door control module rear right																																	
C-CLASS	205		Seat/Door	DCM-RL - Door control module rear left																																	
C-CLASS	205		Seat/Door	DCM-FR - Door control module front right																																	
C-CLASS	205		Seat/Door	DCM-FL - Door control module front left																																	
C-CLASS	205		Seat/Door	RVC/VDS - Convertible roof control																																	
C-CLASS	205		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	124		Drive	PMS/HFM/LH																																	
E-CLASS	124		Drive	ETC - Electronic transmission control																																	
E-CLASS	124		Drive	ISC - Idle speed control																																	
E-CLASS	124		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	124		Body	AB - Airbag																																	
E-CLASS	210		Drive	ME/CDI/CNG - Engine control unit																		V					V										
E-CLASS	210		Drive	ETC - Electronic transmission control																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
E-CLASS	210		Drive	ESM - Electronic selector module																																	
E-CLASS	210		Chassis	ABS/ESP - Electronic stability program																																	
E-CLASS	210		Chassis	VP - Vacuum pump brake booster																																	
E-CLASS	210		Chassis	PSE - Pneumatic system equipment																																	
E-CLASS	210		Chassis	BAS - Brake assist																																	
E-CLASS	210		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	210		Body	OCP - Overhead control panel																													V				
E-CLASS	210		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	210		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	210		Body	AB - Airbag																																	
E-CLASS	210		Information	TV - TV tuner																																	
E-CLASS	210		Information	PTS - Parktronic system																																	
E-CLASS	210		Information	NAV - Navigation module																																	
E-CLASS	210		Information	IC - Instrument cluster																																	
E-CLASS	210		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	210		Information	AUDIO/COMAND																																	
E-CLASS	210		Information	APS - Auto pilot system																																	
E-CLASS	210		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	210		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	210		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	210		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	210		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	210		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	210		Air Conditioning	TSTH/STH - Stationary heater with remote control																														V		V
E-CLASS	210		Air Conditioning	HB - Heater booster																														V		V
E-CLASS	210		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	211		Drive	ME/CDI/CNG - Engine control unit																V		V					V											
E-CLASS	211		Drive	ETC - Electronic transmission control																																	
E-CLASS	211		Drive	ESM - Electronic selector module																																	
E-CLASS	211		Drive	Natural gas control unit																																	
E-CLASS	211		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	211		Drive	DTR - Distronic																																	
E-CLASS	211		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	211		Chassis	ABS/ESP - Electronic stability program																								V	V								
E-CLASS	211		Chassis	Suspension																																	
E-CLASS	211		Chassis	SBC - Sensotronic Brake Control																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
E-CLASS	211		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	211		Body	WSS - Weight sensing system																																	
E-CLASS	211		Body	UCP - Upper control panel																																	
E-CLASS	211		Body	System diagnosis																																	
E-CLASS	211		Body	SCM [MRM] - Steering column module																																	
E-CLASS	211		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	211		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
E-CLASS	211		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	211		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	211		Body	OCP - Overhead control panel																								V									
E-CLASS	211		Body	Multifunction control unit																																	
E-CLASS	211		Body	LCP/HBF - Lower/Rear control panel																																	
E-CLASS	211		Body	LAE [LAA] - Loading floor automatically extendable																																	
E-CLASS	211		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	211		Body	Headlamp-R - Headlamp control unit																											V	V					
E-CLASS	211		Body	Headlamp/Headlamp-L - Headlamp control unit																											V	V					
E-CLASS	211		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	211		Body	CGW - Central gateway																																	
E-CLASS	211		Body	BNS/BMS - Battery sensor																																	
E-CLASS	211		Body	AHE - Trailer recognition																																	
E-CLASS	211		Body	AB - Airbag																																	
E-CLASS	211		Information	TV - TV tuner																																	
E-CLASS	211		Information	SOUND - Sound system																																	
E-CLASS	211		Information	PTS - Parktronic system																																	
E-CLASS	211		Information	MIF/UCI - Media interface																																	
E-CLASS	211		Information	IC - Instrument cluster																																	
E-CLASS	211		Information	DTA - Mbrace or TELEAID/GPS Box																																	
E-CLASS	211		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	211		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	211		Information	AUDIO/COMAND																																	
E-CLASS	211		Information	ASSYST PLUS - PLUS Active Service System																																	
E-CLASS	211		Information	ASSYST Active Service System																																	
E-CLASS	211		Information	AGW - Audio gateway																																	
E-CLASS	211		Seat/Door	REDC/RWT - Rear end door control module																																	
E-CLASS	211		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
E-CLASS	211		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	211		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	211		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	211		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	211		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	211		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	211		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	211		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	211		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	211		Air Conditioning	AAC - Automatic air conditioning																																	
E-CLASS	207		Drive	SG-EM - Power electronics																																	
E-CLASS	207		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	207		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V						V											
E-CLASS	207		Drive	ETC - Electronic transmission control																																	
E-CLASS	207		Drive	ESM - Electronic selector module																																	
E-CLASS	207		Drive	ISM - Intelligent servo module																																	
E-CLASS	207		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	207		Drive	DTR - Distronic																																	
E-CLASS	207		Drive	DSI - Direct select interface																																	
E-CLASS	207		Drive	AMG DRIVE UNIT																																	
E-CLASS	207		Chassis	ABS/ESP - Electronic stability program						V																											
E-CLASS	207		Chassis	Suspension																																	
E-CLASS	207		Chassis	ES - Electrical power steering																																	
E-CLASS	207		Chassis	FWGW - Chassis gateway																																	
E-CLASS	207		Chassis	TPM - Tire pressure monitor																										V							
E-CLASS	207		Body	BNS/BMS - Battery sensor																																	
E-CLASS	207		Body	WSS - Weight sensing system																																	
E-CLASS	207		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	207		Body	SCM [MRM] - Steering column module																																	
E-CLASS	207		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	207		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	207		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	207		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	207		Body	Multifunction control unit																																	
E-CLASS	207		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
E-CLASS	207		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
E-CLASS	207		Body	Headlamp-R - Headlamp control unit																												V	V				
E-CLASS	207		Body	Headlamp/Headlamp-L - Headlamp control unit																												V	V				
E-CLASS	207		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	207		Body	CGW - Central gateway																																	
E-CLASS	207		Body	AHE - Trailer recognition																																	
E-CLASS	207		Body	AB - Airbag																																	
E-CLASS	207		Information	NBR-RF - Right front range radar																																	
E-CLASS	207		Information	NBR-LF - Left front range radar																																	
E-CLASS	207		Information	AVE-H - Rear audio video unit																																	
E-CLASS	207		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	207		Information	ZAN - Audio/COMAND display																																	
E-CLASS	207		Information	TV - TV tuner																																	
E-CLASS	207		Information	SOUND - Sound system																																	
E-CLASS	207		Information	SGR - Radar sensors control unit																																	
E-CLASS	207		Information	360' - Camera																																	
E-CLASS	207		Information	MFK - Multifunction camera																																	
E-CLASS	207		Information	RFK - Backup camera																																	
E-CLASS	207		Information	PTS - Parktronic system																																	
E-CLASS	207		Information	NSA - Night View Assist																																	
E-CLASS	207		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	207		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	207		Information	NAV - Navigation module																																	
E-CLASS	207		Information	MIF/UCI - Media interface																																	
E-CLASS	207		Information	ICI - InCar Internet																																	
E-CLASS	207		Information	IC - Instrument cluster																																	
E-CLASS	207		Information	DVD player																																	
E-CLASS	207		Information	DTA - Mbrace or TELEAID/GPS Box																															V		
E-CLASS	207		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	207		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	207		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	207		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	207		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	207		Information	AUDIO/COMAND																					V	V											
E-CLASS	207		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	207		Seat/Door	PSD/MSC - Sliding roof control																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
E-CLASS	207		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	207		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	207		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	207		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	207		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	207		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	207		Air Conditioning	AAC - Automatic air conditioning														V																			
E-CLASS	212		Drive	SG-EM - Power electronics																																	
E-CLASS	212		Drive	Compressed Natural Gas Control Module																																	
E-CLASS	212		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V							V										
E-CLASS	212		Drive	ETC - Electronic transmission control																																	
E-CLASS	212		Drive	ESM - Electronic selector module																																	
E-CLASS	212		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	212		Drive	ISM - Intelligent servo module																																	
E-CLASS	212		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	212		Drive	DTR - Distronic																																	
E-CLASS	212		Drive	DSI - Direct select interface																																	
E-CLASS	212		Drive	AMG DRIVE UNIT																																	
E-CLASS	212		Chassis	ABS/ESP - Electronic stability program						V																			V	V							
E-CLASS	212		Chassis	Suspension																																	
E-CLASS	212		Chassis	ES - Electrical power steering																																	
E-CLASS	212		Chassis	FWGW - Chassis gateway																																	
E-CLASS	212		Chassis	TPM - Tire pressure monitor																											V						
E-CLASS	212		Body	BNS/BMS - Battery sensor																																	
E-CLASS	212		Body	WSS - Weight sensing system																																	
E-CLASS	212		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	212		Body	SCM [MRM] - Steering column module																																	
E-CLASS	212		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	212		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	212		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	212		Body	OCP - Overhead control panel																																	
E-CLASS	212		Body	Multifunction control unit																																	
E-CLASS	212		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
E-CLASS	212		Body	HSW/LRH - Steering wheel heater																																	
E-CLASS	212		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
E-CLASS	212		Body	Headlamp-R - Headlamp control unit																												V	V				
E-CLASS	212		Body	Headlamp/Headlamp-L - Headlamp control unit																												V	V				
E-CLASS	212		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	212		Body	CGW - Central gateway																																	
E-CLASS	212		Body	AHE - Trailer recognition																																	
E-CLASS	212		Body	AB - Airbag																																	
E-CLASS	212		Information	Head-up display																																	
E-CLASS	212		Information	AVE-H - Rear audio video unit																																	
E-CLASS	212		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
E-CLASS	212		Information	ZAN - Audio/COMAND display																																	
E-CLASS	212		Information	TV - TV tuner																																	
E-CLASS	212		Information	SOUND - Sound system																																	
E-CLASS	212		Information	SGR - Radar sensors control unit																																	
E-CLASS	212		Information	360' - Camera																																	
E-CLASS	212		Information	MFK - Multifunction camera																																	
E-CLASS	212		Information	RFK - Backup camera																																	
E-CLASS	212		Information	PTS - Parktronic system																																	
E-CLASS	212		Information	NSA - Night View Assist																																	
E-CLASS	212		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	212		Information	NBR-RF - Right front range radar																																	
E-CLASS	212		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	212		Information	NBR-LF - Left front range radar																																	
E-CLASS	212		Information	NAV - Navigation module																																	
E-CLASS	212		Information	MIF/UCI - Media interface																																	
E-CLASS	212		Information	ICI - InCar Internet																																	
E-CLASS	212		Information	IC - Instrument cluster																																	
E-CLASS	212		Information	DVD player																																	
E-CLASS	212		Information	DTA - Mbrace or TELEAID/GPS Box																															V		
E-CLASS	212		Information	D-FOR - Display in right rear passenger																																	
E-CLASS	212		Information	D-FOL - Display in left rear passenger																																	
E-CLASS	212		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	212		Information	CTEL/TEL - Cellular/Mobile telephone																																	
E-CLASS	212		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	212		Information	AUDIO/COMAND																					V	V											
E-CLASS	212		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	212		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
E-CLASS	212		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	212		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	212		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	212		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	212		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	212		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	212		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	212		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	212		Air Conditioning	EKMK - Electric refrigerant compressor																																	
E-CLASS	212		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
E-CLASS	212		Air Conditioning	AAC - Automatic air conditioning														V																			
E-CLASS	213		Drive	SCR - Selective catalytic reduction																																	
E-CLASS	213		Drive	DTR - Distronic																																	
E-CLASS	213		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
E-CLASS	213		Drive	HFPM - Haptic accelerator pedal module																																	
E-CLASS	213		Drive	AMG DRIVE UNIT																																	
E-CLASS	213		Drive	PTCU - Common powertrain controller																																	
E-CLASS	213		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
E-CLASS	213		Drive	ETC - Electronic transmission control																																	
E-CLASS	213		Chassis	TPM - Tire pressure monitor																																	
E-CLASS	213		Chassis	AIRMATIC PLUS																																	
E-CLASS	213		Chassis	ES - Electrical power steering																																	
E-CLASS	213		Chassis	Suspension																																	
E-CLASS	213		Chassis	ABS/ESP - Electronic stability program																	V																
E-CLASS	213		Body	MTAS - Mobile phone cradle																																	
E-CLASS	213		Body	AHE - Trailer recognition																																	
E-CLASS	213		Body	SCM [MRM] - Steering column module																																	
E-CLASS	213		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
E-CLASS	213		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
E-CLASS	213		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
E-CLASS	213		Body	AB - Airbag																																	
E-CLASS	213		Body	OCP - Overhead control panel																																	
E-CLASS	213		Body	Multifunction control unit																																	
E-CLASS	213		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
E-CLASS	213		Body	SG-DDW - DC/DC converter control unit																																	
E-CLASS	213		Body	Headlamp-R - Headlamp control unit																																	
E-CLASS	213		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
E-CLASS	213		Body	SG-AWF - Collision prevention assist																																	
E-CLASS	213		Body	EZS/EIS - Electronic ignition lock																																	
E-CLASS	213		Body	BNS/BMS - Battery sensor																																	
E-CLASS	213		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
E-CLASS	213		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
E-CLASS	213		Body	AML - Ambiance light																																	
E-CLASS	213		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
E-CLASS	213		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
E-CLASS	213		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
E-CLASS	213		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
E-CLASS	213		Seat/Door	PSD/MSC - Sliding roof control																																	
E-CLASS	213		Seat/Door	HKS - Tailgate control																																	
E-CLASS	213		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
E-CLASS	213		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
E-CLASS	213		Seat/Door	DCM-RR - Door control module rear right																																	
E-CLASS	213		Seat/Door	DCM-RL - Door control module rear left																																	
E-CLASS	213		Seat/Door	DCM-FR - Door control module front right																																	
E-CLASS	213		Seat/Door	DCM-FL - Door control module front left																																	
E-CLASS	213		Seat/Door	RVC/VDS - Convertible roof control																																	
E-CLASS	213		Information	DAB/SDAR - Digital/Satellite radio																																	
E-CLASS	213		Information	TPAD - Touchpad																																	
E-CLASS	213		Information	Sound generator for exhaust system																																	
E-CLASS	213		Information	SOUND - Sound system																																	
E-CLASS	213		Information	RFK - Backup camera																																	
E-CLASS	213		Information	PTS - Parktronic system																																	
E-CLASS	213		Information	MFK - Multifunction camera																																	
E-CLASS	213		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
E-CLASS	213		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
E-CLASS	213		Information	SGR - Radar sensors control unit																																	
E-CLASS	213		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
E-CLASS	213		Information	Head-up display																																	
E-CLASS	213		Information	AUDIO/COMAND																																	
E-CLASS	213		Information	DTA - Mbrace or TELEAID/GPS Box																																V	
E-CLASS	213		Information	ZAN - Audio/COMAND display																																	
E-CLASS	213		Information	COU [ZBE] - Audio/COMAND operating unit																																	
E-CLASS	213		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	140		Drive	ASF																																	
S-CLASS	140		Drive	ERE																																	
S-CLASS	140		Drive	ME1LI																																	
S-CLASS	140		Drive	ME1RE																																	
S-CLASS	140		Drive	HFM/ME2/LH																																	
S-CLASS	140		Drive	ETC - Electronic transmission control																																	
S-CLASS	140		Drive	ISC - Idle speed control																																	
S-CLASS	140		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	140		Chassis	BAS - Brake assist																																	
S-CLASS	140		Body	PSE - Pneumatic system equipment																																	
S-CLASS	140		Body	AB - Airbag																																	
S-CLASS	140		Information	PTS - Parktronic system																																	
S-CLASS	140		Information	IC - Instrument cluster																																	
S-CLASS	140		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	220		Drive	ME/CDI/CNG - Engine control unit																V		V					V											
S-CLASS	220		Drive	ETC - Electronic transmission control																																	
S-CLASS	220		Drive	ESM - Electronic selector module																																	
S-CLASS	220		Drive	DTR - Distronic																																	
S-CLASS	220		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	220		Chassis	Suspension																																	
S-CLASS	220		Chassis	PSE - Pneumatic system equipment																																	
S-CLASS	220		Chassis	ABS/ESP - Electronic stability program																																	
S-CLASS	220		Body	UCP - Upper control panel																																	
S-CLASS	220		Body	System diagnosis																																	
S-CLASS	220		Body	SCM [MRM] - Steering column module																																	
S-CLASS	220		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	220		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
S-CLASS	220		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	220		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	220		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
S-CLASS	220		Body	OCP - Overhead control panel																																	
S-CLASS	220		Body	Multifunction control unit																																	
S-CLASS	220		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	220		Body	HSW/LRH - Steering wheel heater																																	
S-CLASS	220		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	220		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	220		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	220		Body	CGW - Central gateway																																	
S-CLASS	220		Body	AHE - Trailer recognition																																	
S-CLASS	220		Body	AB - Airbag																																	
S-CLASS	220		Information	TV - TV tuner																																	
S-CLASS	220		Information	PTS - Parktronic system																																	
S-CLASS	220		Information	NAV - Navigation module																																	
S-CLASS	220		Information	IC - Instrument cluster																																	
S-CLASS	220		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	220		Information	AUDIO/COMAND																																	
S-CLASS	220		Information	AGW - Audio gateway																																	
S-CLASS	220		Seat/Door	OSB-R - Multicontour backrest rear																																	
S-CLASS	220		Seat/Door	OSB-FL - Multicontour backrest front left																																	
S-CLASS	220		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	220		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	220		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	220		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	220		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	220		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	220		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	220		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	220		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	220		Air Conditioning	TSTH/STH - Stationary heater with remote control																														V			V
S-CLASS	220		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	220		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	221		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V						V											
S-CLASS	221		Drive	ETC - Electronic transmission control																																	
S-CLASS	221		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	221		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
S-CLASS	221		Drive	HSG - Hybrid control unit																	V																
S-CLASS	221		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	221		Drive	DTR - Distronic																																	
S-CLASS	221		Chassis	ABS/ESP - Electronic stability program						V																			V	V							
S-CLASS	221		Chassis	Suspension																																	
S-CLASS	221		Chassis	ES - Electrical power steering																																	
S-CLASS	221		Chassis	EFB - Electric parking brake																																	
S-CLASS	221		Chassis	TPM - Tire pressure monitor																											V						
S-CLASS	221		Body	WSS - Weight sensing system																																	
S-CLASS	221		Body	UCP - Upper control panel																																	
S-CLASS	221		Body	System diagnosis																																	
S-CLASS	221		Body	SG-DDW - DC/DC converter control unit																																	
S-CLASS	221		Body	SCM [MRM] - Steering column module																																	
S-CLASS	221		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	221		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	221		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	221		Body	OCP - Overhead control panel																																	
S-CLASS	221		Body	Multifunction control unit																																	
S-CLASS	221		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	221		Body	Headlamp-R - Headlamp control unit																												V	V				
S-CLASS	221		Body	Headlamp/Headlamp-L - Headlamp control unit																												V	V				
S-CLASS	221		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	221		Body	CGW - Central gateway																																	
S-CLASS	221		Body	BNS/BMS - Battery sensor																																	
S-CLASS	221		Body	AHE - Trailer recognition																																	
S-CLASS	221		Body	AB - Airbag																																	
S-CLASS	221		Information	ZAN - Audio/COMAND display																																	
S-CLASS	221		Information	VCS - Voice control																																	
S-CLASS	221		Information	TV - TV tuner																																	
S-CLASS	221		Information	Tuner - Standard tuner																																	
S-CLASS	221		Information	SOUND - Sound system																																	
S-CLASS	221		Information	SGR - Radar sensors control unit																																	
S-CLASS	221		Information	MFK - Multifunction camera																																	
S-CLASS	221		Information	RFK - Backup camera																																	
S-CLASS	221		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
S-CLASS	221		Information	NSA - Night View Assist																																	
S-CLASS	221		Information	NBR-LF - Left front range radar																																	
S-CLASS	221		Information	NAV - Navigation module																																	
S-CLASS	221		Information	MIF/UCI - Media interface																																	
S-CLASS	221		Information	ICI - InCar Internet																																	
S-CLASS	221		Information	IC - Instrument cluster																																	
S-CLASS	221		Information	DVD player																																	
S-CLASS	221		Information	DTA - Mbrace or TELEAID/GPS Box																																	
S-CLASS	221		Information	D-FOR - Display in right rear passenger																																	
S-CLASS	221		Information	D-FOL - Display in left rear passenger																																	
S-CLASS	221		Information	DAB/SDAR - Digital/Satellite radio																																	
S-CLASS	221		Information	COU [ZBE] - Audio/COMAND operating unit																																	
S-CLASS	221		Information	AVE-H - Rear audio video unit																																	
S-CLASS	221		Information	AUDIO/COMAND																					V	V											
S-CLASS	221		Information	ASSYST PLUS - PLUS Active Service System																																	
S-CLASS	221		Information	ASSYST Active Service System																																	
S-CLASS	221		Seat/Door	TSG-MR - Right center door control unit																																	
S-CLASS	221		Seat/Door	TSG-ML - Left center door control unit																																	
S-CLASS	221		Seat/Door	TLC/GTO - Garage door opener																																	
S-CLASS	221		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	221		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
S-CLASS	221		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
S-CLASS	221		Seat/Door	HKS - Tailgate control																																	
S-CLASS	221		Seat/Door	ESA-R - Electric seat adjustment rear																																	
S-CLASS	221		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	221		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	221		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	221		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	221		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	221		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	221		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	221		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	221		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	221		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
S-CLASS	221		Air Conditioning	HBF - Rear control panel																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
S-CLASS	221		Air Conditioning	AAC - Automatic air conditioning																																
S-CLASS	217		Drive	SCR - Selective catalytic reduction																																
S-CLASS	217		Drive	SG-EM - Power electronics																																
S-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																
S-CLASS	217		Drive	DTR - Distronic																																
S-CLASS	217		Drive	ISM - Intelligent servo module																																
S-CLASS	217		Drive	PTCU - Common powertrain controller																																
S-CLASS	217		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																
S-CLASS	217		Drive	ETC - Electronic transmission control																																
S-CLASS	217		Chassis	TPM - Tire pressure monitor																																
S-CLASS	217		Chassis	ABS/ESP - Electronic stability program																	V															
S-CLASS	217		Chassis	ES - Electrical power steering																																
S-CLASS	217		Chassis	Suspension																																
S-CLASS	217		Chassis	EFB - Electric parking brake																																
S-CLASS	217		Information	TPAD - Touchpad																																
S-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																
S-CLASS	217		Information	360' - Camera																																
S-CLASS	217		Information	SOUND - Sound system																																
S-CLASS	217		Information	RFK - Backup camera																																
S-CLASS	217		Information	SGR - Radar sensors control unit																																
S-CLASS	217		Information	PTS - Parktronic system																																
S-CLASS	217		Information	NSA - Night View Assist																																
S-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																
S-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																
S-CLASS	217		Information	NBR-RF - Right front range radar																																
S-CLASS	217		Information	NBR-LF - Left front range radar																																
S-CLASS	217		Information	MFK - Multifunction camera																																
S-CLASS	217		Information	Head-up display																																
S-CLASS	217		Information	AUDIO/COMAND																																
S-CLASS	217		Information	ZAN - Audio/COMAND display																																
S-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																
S-CLASS	217		Information	KAB - Camera cover																																
S-CLASS	217		Information	IC - Instrument cluster																																
S-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																														V		
S-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																
S-CLASS	217		Body	SCM [MRM] - Steering column module																																

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
S-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
S-CLASS	217		Body	AB - Airbag																																	
S-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
S-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
S-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
S-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
S-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
S-CLASS	217		Body	BNS/BMS - Battery sensor																																	
S-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	217		Seat/Door	HKS - Tailgate control																																	
S-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
S-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																																	
S-CLASS	222		Drive	SCR - Selective catalytic reduction																																	
S-CLASS	222		Drive	SG-EM - Power electronics																																	
S-CLASS	222		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
S-CLASS	222		Drive	DTR - Distronic																																	
S-CLASS	222		Drive	ISM - Intelligent servo module																																	
S-CLASS	222		Drive	PTCU - Common powertrain controller																																	
S-CLASS	222		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
S-CLASS	222		Drive	ETC - Electronic transmission control																																	
S-CLASS	222		Chassis	TPM - Tire pressure monitor																																	
S-CLASS	222		Chassis	ES - Electrical power steering																																	
S-CLASS	222		Chassis	ABS/ESP - Electronic stability program																	V																
S-CLASS	222		Chassis	Suspension																																	
S-CLASS	222		Chassis	EFB - Electric parking brake																																	
S-CLASS	222		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
S-CLASS	222		Information	DAB/SDAR - Digital/Satellite radio																																
S-CLASS	222		Information	360' - Camera																																
S-CLASS	222		Information	Sound generator for exhaust system																																
S-CLASS	222		Information	SOUND - Sound system																																
S-CLASS	222		Information	RFK - Backup camera																																
S-CLASS	222		Information	SGR - Radar sensors control unit																																
S-CLASS	222		Information	PTS - Parktronic system																																
S-CLASS	222		Information	NSA - Night View Assist																																
S-CLASS	222		Information	NBR-LR/IRS-HLA - Left rear range radar																																
S-CLASS	222		Information	NBR-RR/IRS-HRA - Right rear range radar																																
S-CLASS	222		Information	NBR-RF - Right front range radar																																
S-CLASS	222		Information	NBR-LF - Left front range radar																																
S-CLASS	222		Information	MFK - Multifunction camera																																
S-CLASS	222		Information	Head-up display																																
S-CLASS	222		Information	AUDIO/COMAND																																
S-CLASS	222		Information	AVE-H - Rear audio video unit																																
S-CLASS	222		Information	ZAN - Audio/COMAND display																																
S-CLASS	222		Information	D-FOR - Display in right rear passenger																																
S-CLASS	222		Information	D-FOL - Display in left rear passenger																																
S-CLASS	222		Information	COU [ZBE] - Audio/COMAND operating unit																																
S-CLASS	222		Information	KAB - Camera cover																																
S-CLASS	222		Information	IC - Instrument cluster																																
S-CLASS	222		Information	DTA - Mbrace or TELEAID/GPS Box																														V		
S-CLASS	222		Body	ATA - ATA [EDW]/tow-away/interior protection																																
S-CLASS	222		Body	AHE - Trailer recognition																																
S-CLASS	222		Body	SCM [MRM] - Steering column module																																
S-CLASS	222		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																
S-CLASS	222		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																
S-CLASS	222		Body	AB - Airbag																																
S-CLASS	222		Body	Multifunction control unit																																
S-CLASS	222		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																
S-CLASS	222		Body	Headlamp-R - Headlamp control unit																																
S-CLASS	222		Body	Headlamp/Headlamp-L - Headlamp control unit																																
S-CLASS	222		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																
S-CLASS	222		Body	SG-AWF - Collision prevention assist																																
S-CLASS	222		Body	EZS/EIS - Electronic ignition lock																																

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
S-CLASS	222		Body	BNS/BMS - Battery sensor																																	
S-CLASS	222		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
S-CLASS	222		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
S-CLASS	222		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
S-CLASS	222		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
S-CLASS	222		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
S-CLASS	222		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
S-CLASS	222		Seat/Door	HKS - Tailgate control																																	
S-CLASS	222		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
S-CLASS	222		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
S-CLASS	222		Seat/Door	PSD/MSC - Sliding roof control																																	
S-CLASS	222		Seat/Door	DCM-RR - Door control module rear right																																	
S-CLASS	222		Seat/Door	DCM-RL - Door control module rear left																																	
S-CLASS	222		Seat/Door	DCM-FR - Door control module front right																																	
S-CLASS	222		Seat/Door	DCM-FL - Door control module front left																																	
S-CLASS	222		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
S-CLASS	222		Air Conditioning	AAC - Automatic air conditioning																																	
G-CLASS	461 - 38P Connector		Drive	EVE																																	
G-CLASS	461 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																	
G-CLASS	461 - 38P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 38P Connector		Information	IC - Instrument cluster																																	
G-CLASS	461 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	461 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V		V															
G-CLASS	461 - 16P Connector		Drive	ETC - Electronic transmission control																																	
G-CLASS	461 - 16P Connector		Drive	ESM - Electronic selector module																																	
G-CLASS	461 - 16P Connector		Drive	VG - Transfer case																																	
G-CLASS	461 - 16P Connector		Chassis	ABS/ESP - Electronic stability program																									V	V							
G-CLASS	461 - 16P Connector		Chassis	TPM - Tire pressure monitor																											V						
G-CLASS	461 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
G-CLASS	461 - 16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
G-CLASS	461 - 16P Connector		Body	CGW - Central gateway																																	
G-CLASS	461 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	461 - 16P Connector		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
G-CLASS	461 - 16P Connector		Information	AGW - Audio gateway																																
G-CLASS	461 - 16P Connector		Information	AUDIO/COMAND																																
G-CLASS	461 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																													V		V
G-CLASS	463 - 38P Connector		Drive	ME/CDI/CNG - Engine control unit																																
G-CLASS	463 - 38P Connector		Drive	ETC - Electronic transmission control																																
G-CLASS	463 - 38P Connector		Drive	ESM - Electronic selector module																																
G-CLASS	463 - 38P Connector		Drive	CC - Cruise control																																
G-CLASS	463 - 38P Connector		Chassis	ABS/ESP - Electronic stability program																																
G-CLASS	463 - 38P Connector		Body	AB - Airbag																																
G-CLASS	463 - 38P Connector		Information	IC - Instrument cluster																																
G-CLASS	463 - 38P Connector		Information	AUDIO/COMAND																																
G-CLASS	463 - 38P Connector		Information	APS - Auto pilot system																																
G-CLASS	463 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																													V		V
G-CLASS	463 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V		V					V									
G-CLASS	463 - 16P Connector		Drive	ETC - Electronic transmission control																																
G-CLASS	463 - 16P Connector		Drive	ESM - Electronic selector module																																
G-CLASS	463 - 16P Connector		Drive	VG - Transfer case																																
G-CLASS	463 - 16P Connector		Drive	SCR - Selective catalytic reduction																																
G-CLASS	463 - 16P Connector		Drive	ISM - Intelligent servo module																																
G-CLASS	463 - 16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																
G-CLASS	463 - 16P Connector		Drive	DTR - Distronic																																
G-CLASS	463 - 16P Connector		Drive	DSI - Direct select interface																																
G-CLASS	463 - 16P Connector		Chassis	ABS/ESP - Electronic stability program						V																		V	V							
G-CLASS	463 - 16P Connector		Chassis	TPM - Tire pressure monitor																										V						
G-CLASS	463 - 16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																
G-CLASS	463 - 16P Connector		Body	UCP - Upper control panel																																
G-CLASS	463 - 16P Connector		Body	SCM [MRM] - Steering column module																																
G-CLASS	463 - 16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																
G-CLASS	463 - 16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																
G-CLASS	463 - 16P Connector		Body	OCP - Overhead control panel																							V									
G-CLASS	463 - 16P Connector		Body	Multifunction control unit																																
G-CLASS	463 - 16P Connector		Body	HSW/LRH - Steering wheel heater																																
G-CLASS	463 - 16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																											V	V				
G-CLASS	463 - 16P Connector		Body	EZS/EIS - Electronic ignition lock																																
G-CLASS	463 - 16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																
G-CLASS	463 - 16P Connector		Body	AHE - Trailer recognition																																

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
G-CLASS	463 - 16P Connector		Body	AB - Airbag																																	
G-CLASS	463 - 16P Connector		Information	ZAN - Audio/COMAND display																																	
G-CLASS	463 - 16P Connector		Information	TV - TV tuner																																	
G-CLASS	463 - 16P Connector		Information	SOUND - Sound system																																	
G-CLASS	463 - 16P Connector		Information	PTS - Parktronic system																																	
G-CLASS	463 - 16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
G-CLASS	463 - 16P Connector		Information	NAV - Navigation module																																	
G-CLASS	463 - 16P Connector		Information	MIF/UCI - Media interface																																	
G-CLASS	463 - 16P Connector		Information	IC - Instrument cluster																																	
G-CLASS	463 - 16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																																V	
G-CLASS	463 - 16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																	
G-CLASS	463 - 16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																	
G-CLASS	463 - 16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																	
G-CLASS	463 - 16P Connector		Information	AUDIO/COMAND																					V	V											
G-CLASS	463 - 16P Connector		Information	AGW - Audio gateway																																	
G-CLASS	463 - 16P Connector		Seat/Door	HS - Seat heater																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
G-CLASS	463 - 16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RR - Door control module rear right																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RL - Door control module rear left																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FR - Door control module front right																																	
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FL - Door control module front left																																	
G-CLASS	463 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
G-CLASS	463 - 16P Connector		Air Conditioning	AAC - Automatic air conditioning														V																			
GLA-CLASS	156		Drive	VG - Transfer case																																	
GLA-CLASS	156		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
GLA-CLASS	156		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLA-CLASS	156		Drive	ETC - Electronic transmission control																																	
GLA-CLASS	156		Drive	DTR - Distronic																																	
GLA-CLASS	156		Drive	DSI - Direct select interface																																	
GLA-CLASS	156		Drive	PTCU - Common powertrain controller																																	
GLA-CLASS	156		Chassis	ABS/ESP - Electronic stability program						V																											
GLA-CLASS	156		Chassis	ES - Electrical power steering																																	
GLA-CLASS	156		Chassis	EFB - Electric parking brake																																	
GLA-CLASS	156		Chassis	TPM - Tire pressure monitor																										V							

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
GLA-CLASS	156		Body	SG-AWF - Collision prevention assist																																	
GLA-CLASS	156		Body	SCM [MRM] - Steering column module																																	
GLA-CLASS	156		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLA-CLASS	156		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLA-CLASS	156		Body	Multifunction control unit																																	
GLA-CLASS	156		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLA-CLASS	156		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLA-CLASS	156		Body	EZS/EIS - Electronic ignition lock																																	
GLA-CLASS	156		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLA-CLASS	156		Body	AHE - Trailer recognition																																	
GLA-CLASS	156		Body	AB - Airbag																																	
GLA-CLASS	156		Information	Head-up display																																	
GLA-CLASS	156		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLA-CLASS	156		Information	KAB - Camera cover																																	
GLA-CLASS	156		Information	ZAN - Audio/COMAND display																																	
GLA-CLASS	156		Information	TV - TV tuner																																	
GLA-CLASS	156		Information	SOUND - Sound system																																	
GLA-CLASS	156		Information	RFK - Backup camera																																	
GLA-CLASS	156		Information	MFK - Multifunction camera																																	
GLA-CLASS	156		Information	PTS - Parktronic system																																	
GLA-CLASS	156		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLA-CLASS	156		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLA-CLASS	156		Information	NAV - Navigation module																																	
GLA-CLASS	156		Information	MIF/UCI - Media interface																																	
GLA-CLASS	156		Information	IC - Instrument cluster																																	
GLA-CLASS	156		Information	DTA - Mbrace or TELEAID/GPS Box																															V		
GLA-CLASS	156		Information	DAB/SDAR - Digital/Satellite radio																																	
GLA-CLASS	156		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLA-CLASS	156		Information	AUDIO/COMAND																					V	V											
GLA-CLASS	156		Seat/Door	HKS - Tailgate control																																	
GLA-CLASS	156		Seat/Door	PSD/MSC - Sliding roof control																																	
GLA-CLASS	156		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLA-CLASS	156		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLA-CLASS	156		Seat/Door	DCM-FR - Door control module front right																																	
GLA-CLASS	156		Seat/Door	DCM-FL - Door control module front left																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
GLA-CLASS	156		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLA-CLASS	156		Air Conditioning	AAC - Automatic air conditioning														V																			
GLK-CLASS	204		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V							V										
GLK-CLASS	204		Drive	ETC - Electronic transmission control																																	
GLK-CLASS	204		Drive	ESM - Electronic selector module																																	
GLK-CLASS	204		Drive	SCR - Selective catalytic reduction																																	
GLK-CLASS	204		Drive	PTCU - Common powertrain controller																																	
GLK-CLASS	204		Drive	ISM - Intelligent servo module																																	
GLK-CLASS	204		Drive	FSCU-R - Control unit fuel pump																																	
GLK-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLK-CLASS	204		Drive	DTR - Distronic																																	
GLK-CLASS	204		Drive	AMG DRIVE UNIT																																	
GLK-CLASS	204		Chassis	ABS/ESP - Electronic stability program						V																		V	V								
GLK-CLASS	204		Chassis	Suspension																																	
GLK-CLASS	204		Chassis	ES - Electrical power steering																																	
GLK-CLASS	204		Chassis	TPM - Tire pressure monitor																										V							
GLK-CLASS	204		Body	WSS - Weight sensing system																																	
GLK-CLASS	204		Body	SCM [MRM] - Steering column module																																	
GLK-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLK-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLK-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLK-CLASS	204		Body	OCP - Overhead control panel																																	
GLK-CLASS	204		Body	Multifunction control unit																																	
GLK-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLK-CLASS	204		Body	Headlamp-R - Headlamp control unit																											V	V					
GLK-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit																											V	V					
GLK-CLASS	204		Body	EZS/EIS - Electronic ignition lock																																	
GLK-CLASS	204		Body	CGW - Central gateway																																	
GLK-CLASS	204		Body	AHE - Trailer recognition																																	
GLK-CLASS	204		Body	AB - Airbag																																	
GLK-CLASS	204		Information	Head-up display																																	
GLK-CLASS	204		Information	AVE-H - Rear audio video unit																																	
GLK-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GLK-CLASS	204		Information	ZAN - Audio/COMAND display																																	
GLK-CLASS	204		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
GLK-CLASS	204		Information	Sound generator for exhaust system																																	
GLK-CLASS	204		Information	SOUND - Sound system																																	
GLK-CLASS	204		Information	SGR - Radar sensors control unit																																	
GLK-CLASS	204		Information	360' - Camera																																	
GLK-CLASS	204		Information	MFK - Multifunction camera																																	
GLK-CLASS	204		Information	RFK - Backup camera																																	
GLK-CLASS	204		Information	PTS - Parktronic system																																	
GLK-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLK-CLASS	204		Information	NBR-RF - Right front range radar																																	
GLK-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLK-CLASS	204		Information	NBR-LF - Left front range radar																																	
GLK-CLASS	204		Information	NAV - Navigation module																																	
GLK-CLASS	204		Information	MIF/UCI - Media interface																																	
GLK-CLASS	204		Information	ICI - InCar Internet																																	
GLK-CLASS	204		Information	IC - Instrument cluster																																	
GLK-CLASS	204		Information	DVD player																																	
GLK-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box																															V		
GLK-CLASS	204		Information	D-FOR - Display in right rear passenger																																	
GLK-CLASS	204		Information	D-FOL - Display in left rear passenger																																	
GLK-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio																																	
GLK-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GLK-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLK-CLASS	204		Information	AUDIO/COMAND																					V	V											
GLK-CLASS	204		Information	AMG Performance Media																																	
GLK-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control																																	
GLK-CLASS	204		Seat/Door	HKS - Tailgate control																																	
GLK-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLK-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLK-CLASS	204		Seat/Door	DCM-RR - Door control module rear right																																	
GLK-CLASS	204		Seat/Door	DCM-RL - Door control module rear left																																	
GLK-CLASS	204		Seat/Door	DCM-FR - Door control module front right																																	
GLK-CLASS	204		Seat/Door	DCM-FL - Door control module front left																																	
GLK-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLK-CLASS	204		Air Conditioning	AAC - Automatic air conditioning														V																			
GLC-CLASS	253		Drive	SCR - Selective catalytic reduction																																	
GLC-CLASS	253		Drive	SG-EM - Power electronics																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
GLC-CLASS	253		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLC-CLASS	253		Drive	DTR - Distronic																																	
GLC-CLASS	253		Drive	ISM - Intelligent servo module																																	
GLC-CLASS	253		Drive	PTCU - Common powertrain controller																																	
GLC-CLASS	253		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
GLC-CLASS	253		Drive	ETC - Electronic transmission control																																	
GLC-CLASS	253		Chassis	TPM - Tire pressure monitor																																	
GLC-CLASS	253		Chassis	AIRMATIC PLUS																																	
GLC-CLASS	253		Chassis	ES - Electrical power steering																																	
GLC-CLASS	253		Chassis	Suspension																																	
GLC-CLASS	253		Chassis	ABS/ESP - Electronic stability program																	V																
GLC-CLASS	253		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLC-CLASS	253		Body	AHE - Trailer recognition																																	
GLC-CLASS	253		Body	SCM [MRM] - Steering column module																																	
GLC-CLASS	253		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLC-CLASS	253		Body	AB - Airbag																																	
GLC-CLASS	253		Body	Multifunction control unit																																	
GLC-CLASS	253		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLC-CLASS	253		Body	Headlamp-R - Headlamp control unit																																	
GLC-CLASS	253		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLC-CLASS	253		Body	SG-AWF - Collision prevention assist																																	
GLC-CLASS	253		Body	EZS/EIS - Electronic ignition lock																																	
GLC-CLASS	253		Body	BNS/BMS - Battery sensor																																	
GLC-CLASS	253		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLC-CLASS	253		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLC-CLASS	253		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLC-CLASS	253		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GLC-CLASS	253		Seat/Door	PSD/MSC - Sliding roof control																																	
GLC-CLASS	253		Seat/Door	HKS - Tailgate control																																	
GLC-CLASS	253		Seat/Door	DCM-RR - Door control module rear right																																	
GLC-CLASS	253		Seat/Door	DCM-RL - Door control module rear left																																	
GLC-CLASS	253		Seat/Door	DCM-FR - Door control module front right																																	
GLC-CLASS	253		Seat/Door	DCM-FL - Door control module front left																																	
GLC-CLASS	253		Information	TPAD - Touchpad																																	
GLC-CLASS	253		Information	DAB/SDAR - Digital/Satellite radio																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
GLC-CLASS	253		Information	360' - Camera																																	
GLC-CLASS	253		Information	Sound generator for exhaust system																																	
GLC-CLASS	253		Information	SOUND - Sound system																																	
GLC-CLASS	253		Information	RFK - Backup camera																																	
GLC-CLASS	253		Information	SGR - Radar sensors control unit																																	
GLC-CLASS	253		Information	PTS - Parktronic system																																	
GLC-CLASS	253		Information	NBR-RF - Right front range radar																																	
GLC-CLASS	253		Information	NBR-LF - Left front range radar																																	
GLC-CLASS	253		Information	MFK - Multifunction camera																																	
GLC-CLASS	253		Information	IC - Instrument cluster																																	
GLC-CLASS	253		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLC-CLASS	253		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLC-CLASS	253		Information	Head-up display																																	
GLC-CLASS	253		Information	AUDIO/COMAND																																	
GLC-CLASS	253		Information	SG-MSND - Engine sound																																	
GLC-CLASS	253		Information	ZAN - Audio/COMAND display																																	
GLC-CLASS	253		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLC-CLASS	253		Information	KAB - Camera cover																																	
GLC-CLASS	253		Information	DTA - Mbrace or TELEAID/GPS Box																															V		
GLC-CLASS	253		Information	AMG Performance Media																																	
GLC-CLASS	253		Air Conditioning	AAC - Automatic air conditioning																																	
GLE-CLASS	292		Drive	SCR - Selective catalytic reduction																																	
GLE-CLASS	292		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GLE-CLASS	292		Drive	ISM - Intelligent servo module																																	
GLE-CLASS	292		Drive	DTR - Distronic																																	
GLE-CLASS	292		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
GLE-CLASS	292		Drive	ETC - Electronic transmission control																																	
GLE-CLASS	292		Chassis	TPM - Tire pressure monitor																										V							
GLE-CLASS	292		Chassis	FWGW - Chassis gateway																																	
GLE-CLASS	292		Chassis	ABS/ESP - Electronic stability program						V																		V	V								
GLE-CLASS	292		Chassis	ES - Electrical power steering																																	
GLE-CLASS	292		Chassis	EFB - Electric parking brake																																	
GLE-CLASS	292		Chassis	Suspension																																	
GLE-CLASS	292		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GLE-CLASS	292		Body	AHE - Trailer recognition																																	
GLE-CLASS	292		Body	SCM [MRM] - Steering column module																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
GLE-CLASS	292		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GLE-CLASS	292		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GLE-CLASS	292		Body	AB - Airbag																																	
GLE-CLASS	292		Body	Multifunction control unit																																	
GLE-CLASS	292		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GLE-CLASS	292		Body	Headlamp-R - Headlamp control unit																																	
GLE-CLASS	292		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GLE-CLASS	292		Body	SG-AWF - Collision prevention assist																																	
GLE-CLASS	292		Body	EZS/EIS - Electronic ignition lock																																	
GLE-CLASS	292		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GLE-CLASS	292		Information	TPAD - Touchpad																																	
GLE-CLASS	292		Information	DAB/SDAR - Digital/Satellite radio																																	
GLE-CLASS	292		Information	360' - Camera																																	
GLE-CLASS	292		Information	SOUND - Sound system																																	
GLE-CLASS	292		Information	RFK - Backup camera																																	
GLE-CLASS	292		Information	SGR - Radar sensors control unit																																	
GLE-CLASS	292		Information	PTS - Parktronic system																																	
GLE-CLASS	292		Information	MFK - Multifunction camera																																	
GLE-CLASS	292		Information	NBR-RF - Right front range radar																																	
GLE-CLASS	292		Information	NBR-LF - Left front range radar																																	
GLE-CLASS	292		Information	IC - Instrument cluster																																	
GLE-CLASS	292		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GLE-CLASS	292		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GLE-CLASS	292		Information	Head-up display																																	
GLE-CLASS	292		Information	AUDIO/COMAND																																	
GLE-CLASS	292		Information	AVE-H - Rear audio video unit																																	
GLE-CLASS	292		Information	DVD player																																	
GLE-CLASS	292		Information	SG-MSND - Engine sound																																	
GLE-CLASS	292		Information	ZAN - Audio/COMAND display																																	
GLE-CLASS	292		Information	D-FOR - Display in right rear passenger																																	
GLE-CLASS	292		Information	D-FOL - Display in left rear passenger																																	
GLE-CLASS	292		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GLE-CLASS	292		Information	DTA - Mbrace or TELEAID/GPS Box																															V		
GLE-CLASS	292		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GLE-CLASS	292		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
GLE-CLASS	292		Seat/Door	PSD/MSC - Sliding roof control																																	
GLE-CLASS	292		Seat/Door	HKS - Tailgate control																																	
GLE-CLASS	292		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GLE-CLASS	292		Seat/Door	DCM-RR - Door control module rear right																																	
GLE-CLASS	292		Seat/Door	DCM-RL - Door control module rear left																																	
GLE-CLASS	292		Seat/Door	DCM-FR - Door control module front right																																	
GLE-CLASS	292		Seat/Door	DCM-FL - Door control module front left																																	
GLE-CLASS	292		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GLE-CLASS	292		Air Conditioning	HBF - Rear control panel																																	
GLE-CLASS	292		Air Conditioning	AAC - Automatic air conditioning														V																			
GL-CLASS	164		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V		V					V										
GL-CLASS	164		Drive	ETC - Electronic transmission control																																	
GL-CLASS	164		Drive	VG - Transfer case																																	
GL-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
GL-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
GL-CLASS	164		Drive	SCR - Selective catalytic reduction																																	
GL-CLASS	164		Drive	ISM - Intelligent servo module																																	
GL-CLASS	164		Drive	HSG - Hybrid control unit																	V																
GL-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
GL-CLASS	164		Drive	DTR - Distronic																																	
GL-CLASS	164		Chassis	ABS/ESP - Electronic stability program																									V	V							
GL-CLASS	164		Chassis	Suspension																																	
GL-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
GL-CLASS	164		Chassis	ES - Electrical power steering																																	
GL-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
GL-CLASS	164		Body	WSS - Weight sensing system																																	
GL-CLASS	164		Body	UCP - Upper control panel																																	
GL-CLASS	164		Body	System diagnosis																																	
GL-CLASS	164		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GL-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	164		Body	OCP - Overhead control panel																								V									

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
GL-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
GL-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	164		Body	Headlamp-R - Headlamp control unit																												V	V				
GL-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																												V	V				
GL-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	164		Body	CGW - Central gateway																																	
GL-CLASS	164		Body	AB - Airbag																																	
GL-CLASS	164		Information	TV - TV tuner																																	
GL-CLASS	164		Information	SOUND - Sound system																																	
GL-CLASS	164		Information	RFK - Backup camera																																	
GL-CLASS	164		Information	PTS - Parktronic system																																	
GL-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	164		Information	NAV - Navigation module																																	
GL-CLASS	164		Information	MIF/UCI - Media interface																																	
GL-CLASS	164		Information	IC - Instrument cluster																																	
GL-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
GL-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
GL-CLASS	164		Information	CM - Compass module																																	
GL-CLASS	164		Information	AVE-H - Rear audio video unit																																	
GL-CLASS	164		Information	AUDIO/COMAND																																	
GL-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
GL-CLASS	164		Information	ASSYST Active Service System																																	
GL-CLASS	164		Information	AGW - Audio gateway																																	
GL-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
GL-CLASS	164		Seat/Door	HS - Seat heater																																	
GL-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
GL-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	164		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
GL-CLASS	164		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
GL-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
GL-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
GL-CLASS	166		Drive	SG-EM - Power electronics																																	
GL-CLASS	166		Drive	PTCU - Common powertrain controller																																	
GL-CLASS	166		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
GL-CLASS	166		Drive	ETC - Electronic transmission control																																	
GL-CLASS	166		Drive	VG - Transfer case																																	
GL-CLASS	166		Drive	SCR - Selective catalytic reduction																																	
GL-CLASS	166		Drive	ISM - Intelligent servo module																																	
GL-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
GL-CLASS	166		Drive	DTR - Distronic																																	
GL-CLASS	166		Chassis	ABS/ESP - Electronic stability program						V																			V	V							
GL-CLASS	166		Chassis	Suspension																																	
GL-CLASS	166		Chassis	ES - Electrical power steering																																	
GL-CLASS	166		Chassis	EFB - Electric parking brake																																	
GL-CLASS	166		Chassis	FWGW - Chassis gateway																																	
GL-CLASS	166		Chassis	TPM - Tire pressure monitor																											V						
GL-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
GL-CLASS	166		Body	SCM [MRM] - Steering column module																																	
GL-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
GL-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
GL-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
GL-CLASS	166		Body	Multifunction control unit																																	
GL-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
GL-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
GL-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
GL-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																	
GL-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
GL-CLASS	166		Body	AHE - Trailer recognition																																	
GL-CLASS	166		Body	AB - Airbag																																	
GL-CLASS	166		Information	Sound generator for exhaust system																																	
GL-CLASS	166		Information	Head-up display																																	
GL-CLASS	166		Information	AVE-H - Rear audio video unit																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
GL-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
GL-CLASS	166		Information	ZAN - Audio/COMAND display																																	
GL-CLASS	166		Information	TV - TV tuner																																	
GL-CLASS	166		Information	SOUND - Sound system																																	
GL-CLASS	166		Information	SGR - Radar sensors control unit																																	
GL-CLASS	166		Information	360' - Camera																																	
GL-CLASS	166		Information	RFK - Backup camera																																	
GL-CLASS	166		Information	MFK - Multifunction camera																																	
GL-CLASS	166		Information	PTS - Parktronic system																																	
GL-CLASS	166		Information	NSA - Night View Assist																																	
GL-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
GL-CLASS	166		Information	NBR-RF - Right front range radar																																	
GL-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
GL-CLASS	166		Information	NBR-LF - Left front range radar																																	
GL-CLASS	166		Information	NAV - Navigation module																																	
GL-CLASS	166		Information	MIF/UCI - Media interface																																	
GL-CLASS	166		Information	IC - Instrument cluster																																	
GL-CLASS	166		Information	DVD player																																	
GL-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																															V		
GL-CLASS	166		Information	D-FOR - Display in right rear passenger																																	
GL-CLASS	166		Information	D-FOL - Display in left rear passenger																																	
GL-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																	
GL-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																	
GL-CLASS	166		Information	AUDIO/COMAND																					V	V											
GL-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																	
GL-CLASS	166		Seat/Door	HKS - Tailgate control																																	
GL-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
GL-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
GL-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
GL-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
GL-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
GL-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
GL-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
GL-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
GL-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
GL-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
GL-CLASS	166		Air Conditioning	AAC - Automatic air conditioning														V																			
M-CLASS	163		Drive	ME/CDI/CNG - Engine control unit																		V															
M-CLASS	163		Drive	ETC - Electronic transmission control																																	
M-CLASS	163		Drive	ESM - Electronic selector module																																	
M-CLASS	163		Drive	VG - Transfer case																																	
M-CLASS	163		Chassis	ABS/ESP - Electronic stability program																									V	V							
M-CLASS	163		Chassis	VP - Vacuum pump brake booster																																	
M-CLASS	163		Chassis	BAS - Brake assist																																	
M-CLASS	163		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
M-CLASS	163		Body	AB - Airbag																																	
M-CLASS	163		Body	AAM - All activity module																																	
M-CLASS	163		Information	PTS - Parktronic system																																	
M-CLASS	163		Information	IC - Instrument cluster																																	
M-CLASS	163		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	163		Information	AUDIO/COMAND																																	
M-CLASS	163		Air Conditioning	AAC - Automatic air conditioning																			V	V													
M-CLASS	163		Air Conditioning	TSTH/STH - Stationary heater with remote control																														V		V
M-CLASS	164		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V		V					V										
M-CLASS	164		Drive	ETC - Electronic transmission control																																	
M-CLASS	164		Drive	VG - Transfer case																																	
M-CLASS	164		Drive	SG-EM-B - Electric motor control unit B																																	
M-CLASS	164		Drive	SG-EM-A - Electric motor control unit A																																	
M-CLASS	164		Drive	SCR - Selective catalytic reduction																																	
M-CLASS	164		Drive	ISM - Intelligent servo module																																	
M-CLASS	164		Drive	HSG - Hybrid control unit																	V																
M-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter																																	
M-CLASS	164		Drive	DTR - Distronic																																	
M-CLASS	164		Chassis	ABS/ESP - Electronic stability program																									V	V							
M-CLASS	164		Chassis	Suspension																																	
M-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle																																	
M-CLASS	164		Chassis	ES - Electrical power steering																																	
M-CLASS	164		Chassis	TPM - Tire pressure monitor																																	
M-CLASS	164		Body	WSS - Weight sensing system																																	
M-CLASS	164		Body	UCP - Upper control panel																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
M-CLASS	164		Body	System diagnosis																																	
M-CLASS	164		Body	SCM [MRM] - Steering column module																																	
M-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
M-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	164		Body	OCP - Overhead control panel																								V									
M-CLASS	164		Body	LCP/HBF - Lower/Rear control panel																																	
M-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	164		Body	Headlamp-R - Headlamp control unit																												V	V				
M-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit																												V	V				
M-CLASS	164		Body	EZS/EIS - Electronic ignition lock																																	
M-CLASS	164		Body	CGW - Central gateway																																	
M-CLASS	164		Body	AB - Airbag																																	
M-CLASS	164		Information	TV - TV tuner																																	
M-CLASS	164		Information	SOUND - Sound system																																	
M-CLASS	164		Information	RFK - Backup camera																																	
M-CLASS	164		Information	PTS - Parktronic system																																	
M-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
M-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
M-CLASS	164		Information	NAV - Navigation module																																	
M-CLASS	164		Information	MIF/UCI - Media interface																																	
M-CLASS	164		Information	IC - Instrument cluster																																	
M-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box																																	
M-CLASS	164		Information	D-FOR - Display in right rear passenger																																	
M-CLASS	164		Information	D-FOL - Display in left rear passenger																																	
M-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio																																	
M-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone																																	
M-CLASS	164		Information	CM - Compass module																																	
M-CLASS	164		Information	AVE-H - Rear audio video unit																																	
M-CLASS	164		Information	AUDIO/COMAND																																	
M-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System																																	
M-CLASS	164		Information	ASSYST Active Service System																																	
M-CLASS	164		Information	AGW - Audio gateway																																	
M-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module																																	
M-CLASS	164		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
M-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
M-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
M-CLASS	164		Seat/Door	ERA - Electric fold down backrest system																																	
M-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	164		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	164		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor																																	
M-CLASS	164		Air Conditioning	AAC - Automatic air conditioning																																	
M-CLASS	166		Drive	SG-EM - Power electronics																																	
M-CLASS	166		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
M-CLASS	166		Drive	ETC - Electronic transmission control																																	
M-CLASS	166		Drive	VG - Transfer case																																	
M-CLASS	166		Drive	SCR - Selective catalytic reduction																																	
M-CLASS	166		Drive	PTCU - Common powertrain controller																																	
M-CLASS	166		Drive	ISM - Intelligent servo module																																	
M-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
M-CLASS	166		Drive	DTR - Distronic																																	
M-CLASS	166		Chassis	ABS/ESP - Electronic stability program						V																		V	V								
M-CLASS	166		Chassis	Suspension																																	
M-CLASS	166		Chassis	ES - Electrical power steering																																	
M-CLASS	166		Chassis	EFB - Electric parking brake																																	
M-CLASS	166		Chassis	FWGW - Chassis gateway																																	
M-CLASS	166		Chassis	TPM - Tire pressure monitor																										V							
M-CLASS	166		Body	SG-AWF - Collision prevention assist																																	
M-CLASS	166		Body	SCM [MRM] - Steering column module																																	
M-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
M-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
M-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
M-CLASS	166		Body	Multifunction control unit																																	
M-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
M-CLASS	166		Body	Headlamp-R - Headlamp control unit																																	
M-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
M-CLASS	166		Body	EZS/EIS - Electronic ignition lock																																
M-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection																																
M-CLASS	166		Body	AHE - Trailer recognition																																
M-CLASS	166		Body	AB - Airbag																																
M-CLASS	166		Information	Sound generator for exhaust system																																
M-CLASS	166		Information	Head-up display																																
M-CLASS	166		Information	AVE-H - Rear audio video unit																																
M-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)																																
M-CLASS	166		Information	ZAN - Audio/COMAND display																																
M-CLASS	166		Information	TV - TV tuner																																
M-CLASS	166		Information	SOUND - Sound system																																
M-CLASS	166		Information	SGR - Radar sensors control unit																																
M-CLASS	166		Information	360' - Camera																																
M-CLASS	166		Information	RFK - Backup camera																																
M-CLASS	166		Information	MFK - Multifunction camera																																
M-CLASS	166		Information	PTS - Parktronic system																																
M-CLASS	166		Information	NSA - Night View Assist																																
M-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar																																
M-CLASS	166		Information	NBR-RF - Right front range radar																																
M-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar																																
M-CLASS	166		Information	NBR-LF - Left front range radar																																
M-CLASS	166		Information	NAV - Navigation module																																
M-CLASS	166		Information	MIF/UCI - Media interface																																
M-CLASS	166		Information	IC - Instrument cluster																																
M-CLASS	166		Information	DVD player																																
M-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box																														V		
M-CLASS	166		Information	D-FOR - Display in right rear passenger																																
M-CLASS	166		Information	D-FOL - Display in left rear passenger																																
M-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio																																
M-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit																																
M-CLASS	166		Information	AUDIO/COMAND																					V	V										
M-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control																																
M-CLASS	166		Seat/Door	HKS - Tailgate control																																
M-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																
M-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver																																
M-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
M-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
M-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
M-CLASS	166		Seat/Door	DCM-RR - Door control module rear right																																	
M-CLASS	166		Seat/Door	DCM-RL - Door control module rear left																																	
M-CLASS	166		Seat/Door	DCM-FR - Door control module front right																																	
M-CLASS	166		Seat/Door	DCM-FL - Door control module front left																																	
M-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
M-CLASS	166		Air Conditioning	HBF - Rear control panel																																	
M-CLASS	166		Air Conditioning	AAC - Automatic air conditioning														V																			
R-CLASS	251		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V		V					V										
R-CLASS	251		Drive	ETC - Electronic transmission control																																	
R-CLASS	251		Drive	SCR - Selective catalytic reduction																																	
R-CLASS	251		Drive	ISM - Intelligent servo module																																	
R-CLASS	251		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
R-CLASS	251		Drive	DTR - Distronic																																	
R-CLASS	251		Chassis	ABS/ESP - Electronic stability program																									V	V							
R-CLASS	251		Chassis	Suspension																																	
R-CLASS	251		Chassis	ES - Electrical power steering																																	
R-CLASS	251		Chassis	TPM - Tire pressure monitor																																	
R-CLASS	251		Body	WSS - Weight sensing system																																	
R-CLASS	251		Body	UCP - Upper control panel																																	
R-CLASS	251		Body	System diagnosis																																	
R-CLASS	251		Body	SCM [MRM] - Steering column module																																	
R-CLASS	251		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
R-CLASS	251		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
R-CLASS	251		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
R-CLASS	251		Body	OCP - Overhead control panel																								V									
R-CLASS	251		Body	LCP/HBF - Lower/Rear control panel																																	
R-CLASS	251		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
R-CLASS	251		Body	Headlamp-R - Headlamp control unit																																	
R-CLASS	251		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
R-CLASS	251		Body	EZS/EIS - Electronic ignition lock																																	
R-CLASS	251		Body	CGW - Central gateway																																	
R-CLASS	251		Body	AB - Airbag																																	
R-CLASS	251		Information	TV - TV tuner																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
R-CLASS	251		Information	SOUND - Sound system																																	
R-CLASS	251		Information	RFK - Backup camera																																	
R-CLASS	251		Information	PTS - Parktronic system																																	
R-CLASS	251		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
R-CLASS	251		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
R-CLASS	251		Information	NAV - Navigation module																																	
R-CLASS	251		Information	MIF/UCI - Media interface																																	
R-CLASS	251		Information	IC - Instrument cluster																																	
R-CLASS	251		Information	DTA - Mbrace or TELEAID/GPS Box																																	
R-CLASS	251		Information	D-FOR - Display in right rear passenger																																	
R-CLASS	251		Information	D-FOL - Display in left rear passenger																																	
R-CLASS	251		Information	DAB/SDAR - Digital/Satellite radio																																	
R-CLASS	251		Information	CTEL/TEL - Cellular/Mobile telephone																																	
R-CLASS	251		Information	CM - Compass module																																	
R-CLASS	251		Information	AVE-H - Rear audio video unit																																	
R-CLASS	251		Information	AUDIO/COMAND																																	
R-CLASS	251		Information	ASSYST PLUS - PLUS Active Service System																																	
R-CLASS	251		Information	ASSYST Active Service System																																	
R-CLASS	251		Information	AGW - Audio gateway																																	
R-CLASS	251		Seat/Door	REDC/RWT - Rear end door control module																																	
R-CLASS	251		Seat/Door	HS - Seat heater																																	
R-CLASS	251		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
R-CLASS	251		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
R-CLASS	251		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
R-CLASS	251		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
R-CLASS	251		Seat/Door	DCM-FR - Door control module front right																																	
R-CLASS	251		Seat/Door	DCM-FL - Door control module front left																																	
R-CLASS	251		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
R-CLASS	251		Air Conditioning	AAC - Automatic air conditioning																																	
CLA-CLASS	117		Drive	VG - Transfer case																																	
CLA-CLASS	117		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
CLA-CLASS	117		Drive	ETC - Electronic transmission control																																	
CLA-CLASS	117		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLA-CLASS	117		Drive	DTR - Distronic																																	
CLA-CLASS	117		Drive	DSI - Direct select interface																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
CLA-CLASS	117		Drive	PTCU - Common powertrain controller																																	
CLA-CLASS	117		Chassis	ABS/ESP - Electronic stability program						V																											
CLA-CLASS	117		Chassis	ES - Electrical power steering																																	
CLA-CLASS	117		Chassis	EFB - Electric parking brake																																	
CLA-CLASS	117		Chassis	TPM - Tire pressure monitor																										V							
CLA-CLASS	117		Body	SG-AWF - Collision prevention assist																																	
CLA-CLASS	117		Body	SCM [MRM] - Steering column module																																	
CLA-CLASS	117		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLA-CLASS	117		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLA-CLASS	117		Body	Multifunction control unit																																	
CLA-CLASS	117		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLA-CLASS	117		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLA-CLASS	117		Body	EZS/EIS - Electronic ignition lock																																	
CLA-CLASS	117		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CLA-CLASS	117		Body	AHE - Trailer recognition																																	
CLA-CLASS	117		Body	AB - Airbag																																	
CLA-CLASS	117		Information	Head-up display																																	
CLA-CLASS	117		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLA-CLASS	117		Information	KAB - Camera cover																																	
CLA-CLASS	117		Information	ZAN - Audio/COMAND display																																	
CLA-CLASS	117		Information	TV - TV tuner																																	
CLA-CLASS	117		Information	SOUND - Sound system																																	
CLA-CLASS	117		Information	RFK - Backup camera																																	
CLA-CLASS	117		Information	MFK - Multifunction camera																																	
CLA-CLASS	117		Information	PTS - Parktronic system																																	
CLA-CLASS	117		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLA-CLASS	117		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLA-CLASS	117		Information	NAV - Navigation module																																	
CLA-CLASS	117		Information	MIF/UCI - Media interface																																	
CLA-CLASS	117		Information	IC - Instrument cluster																																	
CLA-CLASS	117		Information	DTA - Mbrace or TELEAID/GPS Box																															V		
CLA-CLASS	117		Information	DAB/SDAR - Digital/Satellite radio																																	
CLA-CLASS	117		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLA-CLASS	117		Information	AUDIO/COMAND																					V	V											
CLA-CLASS	117		Seat/Door	HKS - Tailgate control																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
CLA-CLASS	117		Seat/Door	PSD/MSC - Sliding roof control																																	
CLA-CLASS	117		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLA-CLASS	117		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLA-CLASS	117		Seat/Door	DCM-FR - Door control module front right																																	
CLA-CLASS	117		Seat/Door	DCM-FL - Door control module front left																																	
CLA-CLASS	117		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLA-CLASS	117		Air Conditioning	AAC - Automatic air conditioning														V																			
CLK-CLASS	208		Drive	ME/CDI/CNG - Engine control unit																						V											
CLK-CLASS	208		Drive	ETC - Electronic transmission control																																	
CLK-CLASS	208		Drive	ESM - Electronic selector module																																	
CLK-CLASS	208		Chassis	PSE - Pneumatic system equipment																																	
CLK-CLASS	208		Chassis	ABS/ESP - Electronic stability program																																	
CLK-CLASS	208		Chassis	VP - Vacuum pump brake booster																																	
CLK-CLASS	208		Chassis	BAS - Brake assist																																	
CLK-CLASS	208		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	208		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	208		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	208		Body	OCP - Overhead control panel																													V				
CLK-CLASS	208		Body	AB - Airbag																																	
CLK-CLASS	208		Information	TV - TV tuner																																	
CLK-CLASS	208		Information	PTS - Parktronic system																																	
CLK-CLASS	208		Information	NAV - Navigation module																																	
CLK-CLASS	208		Information	IC - Instrument cluster																																	
CLK-CLASS	208		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	208		Information	AUDIO/COMAND																																	
CLK-CLASS	208		Information	APS - Auto pilot system																																	
CLK-CLASS	208		Air Conditioning	TSTH/STH - Stationary heater with remote control																														V		V
CLK-CLASS	208		Air Conditioning	AAC - Automatic air conditioning																																	
CLK-CLASS	208		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	208		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	208		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	208		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Drive	ME/CDI/CNG - Engine control unit																V		V				V											
CLK-CLASS	209		Drive	ETC - Electronic transmission control																																	
CLK-CLASS	209		Drive	ESM - Electronic selector module																																	
CLK-CLASS	209		Drive	DTR - Distronic																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
CLK-CLASS	209		Chassis	ABS/ESP - Electronic stability program																									V	V							
CLK-CLASS	209		Chassis	TPM - Tire pressure monitor																																	
CLK-CLASS	209		Body	WSS - Weight sensing system																																	
CLK-CLASS	209		Body	UCP - Upper control panel																																	
CLK-CLASS	209		Body	SCM [MRM] - Steering column module																																	
CLK-CLASS	209		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLK-CLASS	209		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLK-CLASS	209		Body	RCM - Rear control module																																	
CLK-CLASS	209		Body	OCP - Overhead control panel																								V									
CLK-CLASS	209		Body	Multifunction control unit																																	
CLK-CLASS	209		Body	LCP/HBF - Lower/Rear control panel																																	
CLK-CLASS	209		Body	Headlamp-R - Headlamp control unit																																	
CLK-CLASS	209		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLK-CLASS	209		Body	EZS/EIS - Electronic ignition lock																																	
CLK-CLASS	209		Body	BNS/BMS - Battery sensor																																	
CLK-CLASS	209		Body	AHE - Trailer recognition																																	
CLK-CLASS	209		Body	AB - Airbag																																	
CLK-CLASS	209		Information	TV - TV tuner																																	
CLK-CLASS	209		Information	PTS - Parktronic system																																	
CLK-CLASS	209		Information	NAV - Navigation module																																	
CLK-CLASS	209		Information	IC - Instrument cluster																																	
CLK-CLASS	209		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLK-CLASS	209		Information	AUDIO/COMAND																																	
CLK-CLASS	209		Information	AGW - Audio gateway																																	
CLK-CLASS	209		Seat/Door	RVC/VDS - Convertible roof control																																	
CLK-CLASS	209		Seat/Door	REDC/RWT - Rear end door control module																																	
CLK-CLASS	209		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLK-CLASS	209		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLK-CLASS	209		Seat/Door	DCM-FR - Door control module front right																																	
CLK-CLASS	209		Seat/Door	DCM-FL - Door control module front left																																	
CLK-CLASS	209		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLK-CLASS	209		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	219		Drive	ME/CDI/CNG - Engine control unit																V		V					V											
CLS-CLASS	219		Drive	ETC - Electronic transmission control																																	
CLS-CLASS	219		Drive	ESM - Electronic selector module																																	
CLS-CLASS	219		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
CLS-CLASS	219		Drive	DTR - Distronic																																	
CLS-CLASS	219		Chassis	ABS/ESP - Electronic stability program																									V	V							
CLS-CLASS	219		Chassis	Suspension																																	
CLS-CLASS	219		Chassis	SBC - Sensotronic Brake Control																																	
CLS-CLASS	219		Chassis	TPM - Tire pressure monitor																																	
CLS-CLASS	219		Body	WSS - Weight sensing system																																	
CLS-CLASS	219		Body	UCP - Upper control panel																																	
CLS-CLASS	219		Body	System diagnosis																																	
CLS-CLASS	219		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	219		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	219		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CLS-CLASS	219		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLS-CLASS	219		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	219		Body	OCP - Overhead control panel																								V									
CLS-CLASS	219		Body	LCP/HBF - Lower/Rear control panel																																	
CLS-CLASS	219		Body	LAE [LAA] - Loading floor automatically extendable																																	
CLS-CLASS	219		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	219		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	219		Body	CGW - Central gateway																																	
CLS-CLASS	219		Body	BNS/BMS - Battery sensor																																	
CLS-CLASS	219		Body	AB - Airbag																																	
CLS-CLASS	219		Information	TV - TV tuner																																	
CLS-CLASS	219		Information	SOUND - Sound system																																	
CLS-CLASS	219		Information	PTS - Parktronic system																																	
CLS-CLASS	219		Information	MIF/UCI - Media interface																																	
CLS-CLASS	219		Information	IC - Instrument cluster																																	
CLS-CLASS	219		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CLS-CLASS	219		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	219		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	219		Information	AUDIO/COMAND																																	
CLS-CLASS	219		Information	ASSYST PLUS - PLUS Active Service System																																	
CLS-CLASS	219		Information	ASSYST Active Service System																																	
CLS-CLASS	219		Information	AGW - Audio gateway																																	
CLS-CLASS	219		Seat/Door	REDC/RWT - Rear end door control module																																	
CLS-CLASS	219		Seat/Door	HS - Seat heater																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
CLS-CLASS	219		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	219		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	219		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	219		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	219		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	219		Seat/Door	DCM-RL - Door control module rear left																																	
CLS-CLASS	219		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	219		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	219		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	219		Air Conditioning	AAC - Automatic air conditioning																																	
CLS-CLASS	218		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V						V											
CLS-CLASS	218		Drive	ETC - Electronic transmission control																																	
CLS-CLASS	218		Drive	ESM - Electronic selector module																																	
CLS-CLASS	218		Drive	SCR - Selective catalytic reduction																																	
CLS-CLASS	218		Drive	ISM - Intelligent servo module																																	
CLS-CLASS	218		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CLS-CLASS	218		Drive	DTR - Distronic																																	
CLS-CLASS	218		Drive	DSI - Direct select interface																																	
CLS-CLASS	218		Drive	AMG DRIVE UNIT																																	
CLS-CLASS	218		Chassis	ABS/ESP - Electronic stability program						V																											
CLS-CLASS	218		Chassis	Suspension																																	
CLS-CLASS	218		Chassis	ES - Electrical power steering																																	
CLS-CLASS	218		Chassis	FWGW - Chassis gateway																																	
CLS-CLASS	218		Chassis	TPM - Tire pressure monitor																										V							
CLS-CLASS	218		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
CLS-CLASS	218		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
CLS-CLASS	218		Body	WSS - Weight sensing system																																	
CLS-CLASS	218		Body	SG-AWF - Collision prevention assist																																	
CLS-CLASS	218		Body	SCM [MRM] - Steering column module																																	
CLS-CLASS	218		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CLS-CLASS	218		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CLS-CLASS	218		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CLS-CLASS	218		Body	OCP - Overhead control panel																																	
CLS-CLASS	218		Body	Multifunction control unit																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
CLS-CLASS	218		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CLS-CLASS	218		Body	HSW/LRH - Steering wheel heater																																	
CLS-CLASS	218		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
CLS-CLASS	218		Body	Headlamp-R - Headlamp control unit																																	
CLS-CLASS	218		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CLS-CLASS	218		Body	EZS/EIS - Electronic ignition lock																																	
CLS-CLASS	218		Body	CGW - Central gateway																																	
CLS-CLASS	218		Body	AHE - Trailer recognition																																	
CLS-CLASS	218		Body	AB - Airbag																																	
CLS-CLASS	218		Information	360' - Camera																																	
CLS-CLASS	218		Information	AVE-H - Rear audio video unit																																	
CLS-CLASS	218		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
CLS-CLASS	218		Information	ZAN - Audio/COMAND display																																	
CLS-CLASS	218		Information	TV - TV tuner																																	
CLS-CLASS	218		Information	SOUND - Sound system																																	
CLS-CLASS	218		Information	SGR - Radar sensors control unit																																	
CLS-CLASS	218		Information	MFK - Multifunction camera																																	
CLS-CLASS	218		Information	RFK - Backup camera																																	
CLS-CLASS	218		Information	PTS - Parktronic system																																	
CLS-CLASS	218		Information	NSA - Night View Assist																																	
CLS-CLASS	218		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CLS-CLASS	218		Information	NBR-RF - Right front range radar																																	
CLS-CLASS	218		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CLS-CLASS	218		Information	NBR-LF - Left front range radar																																	
CLS-CLASS	218		Information	NAV - Navigation module																																	
CLS-CLASS	218		Information	MIF/UCI - Media interface																																	
CLS-CLASS	218		Information	ICI - InCar Internet																																	
CLS-CLASS	218		Information	IC - Instrument cluster																																	
CLS-CLASS	218		Information	DVD player																																	
CLS-CLASS	218		Information	DTA - Mbrace or TELEAID/GPS Box																															V		
CLS-CLASS	218		Information	D-FOR - Display in right rear passenger																																	
CLS-CLASS	218		Information	D-FOL - Display in left rear passenger																																	
CLS-CLASS	218		Information	DAB/SDAR - Digital/Satellite radio																																	
CLS-CLASS	218		Information	CTEL/TEL - Cellular/Mobile telephone																																	
CLS-CLASS	218		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CLS-CLASS	218		Information	AUDIO/COMAND																					V	V											

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
CLS-CLASS	218		Seat/Door	PSD/MSC - Sliding roof control																																	
CLS-CLASS	218		Seat/Door	HKS - Tailgate control																																	
CLS-CLASS	218		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CLS-CLASS	218		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CLS-CLASS	218		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CLS-CLASS	218		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CLS-CLASS	218		Seat/Door	DCM-RR - Door control module rear right																																	
CLS-CLASS	218		Seat/Door	DCM-RL - Door control module rear left																																	
CLS-CLASS	218		Seat/Door	DCM-FR - Door control module front right																																	
CLS-CLASS	218		Seat/Door	DCM-FL - Door control module front left																																	
CLS-CLASS	218		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CLS-CLASS	218		Air Conditioning	AAC - Automatic air conditioning														V																			
CL-CLASS	215		Drive	ME/CDI/CNG - Engine control unit																																	
CL-CLASS	215		Drive	ETC - Electronic transmission control																																	
CL-CLASS	215		Drive	ESM - Electronic selector module																																	
CL-CLASS	215		Drive	DTR - Distronic																																	
CL-CLASS	215		Chassis	ABS/ESP - Electronic stability program																																	
CL-CLASS	215		Chassis	Suspension																																	
CL-CLASS	215		Chassis	PSE - Pneumatic system equipment																																	
CL-CLASS	215		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	215		Body	UCP - Upper control panel																																	
CL-CLASS	215		Body	System diagnosis																																	
CL-CLASS	215		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	215		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	215		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
CL-CLASS	215		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	215		Body	RCM - Rear control module																																	
CL-CLASS	215		Body	OCP - Overhead control panel																																	
CL-CLASS	215		Body	Multifunction control unit																																	
CL-CLASS	215		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	215		Body	HSW/LRH - Steering wheel heater																																	
CL-CLASS	215		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	215		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	215		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	215		Body	CGW - Central gateway																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
CL-CLASS	215		Body	AHE - Trailer recognition																																	
CL-CLASS	215		Body	AB - Airbag																																	
CL-CLASS	215		Information	TV - TV tuner																																	
CL-CLASS	215		Information	PTS - Parktronic system																																	
CL-CLASS	215		Information	NAV - Navigation module																																	
CL-CLASS	215		Information	IC - Instrument cluster																																	
CL-CLASS	215		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	215		Information	AUDIO/COMAND																																	
CL-CLASS	215		Information	AGW - Audio gateway																																	
CL-CLASS	215		Seat/Door	OSB-FR - Multicontour backrest front right																																	
CL-CLASS	215		Seat/Door	OSB-FL - Multicontour backrest front left																																	
CL-CLASS	215		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	215		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	215		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	215		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	215		Air Conditioning	TSTH/STH - Stationary heater with remote control																														V			V
CL-CLASS	215		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
CL-CLASS	215		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	216		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V						V											
CL-CLASS	216		Drive	ETC - Electronic transmission control																																	
CL-CLASS	216		Drive	ISM - Intelligent servo module																																	
CL-CLASS	216		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	216		Drive	DTR - Distronic																																	
CL-CLASS	216		Chassis	ABS/ESP - Electronic stability program						V																		V	V								
CL-CLASS	216		Chassis	Suspension																																	
CL-CLASS	216		Chassis	ES - Electrical power steering																																	
CL-CLASS	216		Chassis	EFB - Electric parking brake																																	
CL-CLASS	216		Chassis	TPM - Tire pressure monitor																										V							
CL-CLASS	216		Body	WSS - Weight sensing system																																	
CL-CLASS	216		Body	UCP - Upper control panel																																	
CL-CLASS	216		Body	System diagnosis																																	
CL-CLASS	216		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	216		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	216		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	216		Body	RCM - Rear control module																																	
CL-CLASS	216		Body	OCP - Overhead control panel																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
CL-CLASS	216		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	216		Body	Headlamp-R - Headlamp control unit																												V	V				
CL-CLASS	216		Body	Headlamp/Headlamp-L - Headlamp control unit																												V	V				
CL-CLASS	216		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	216		Body	CGW - Central gateway																																	
CL-CLASS	216		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	216		Body	AHE - Trailer recognition																																	
CL-CLASS	216		Body	AB - Airbag																																	
CL-CLASS	216		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	216		Information	VCS - Voice control																																	
CL-CLASS	216		Information	TV - TV tuner																																	
CL-CLASS	216		Information	Tuner - Standard tuner																																	
CL-CLASS	216		Information	SGR - Radar sensors control unit																																	
CL-CLASS	216		Information	MFK - Multifunction camera																																	
CL-CLASS	216		Information	RFK - Backup camera																																	
CL-CLASS	216		Information	PTS - Parktronic system																																	
CL-CLASS	216		Information	NSA - Night View Assist																																	
CL-CLASS	216		Information	NBR-LF - Left front range radar																																	
CL-CLASS	216		Information	NAV - Navigation module																																	
CL-CLASS	216		Information	MIF/UCI - Media interface																																	
CL-CLASS	216		Information	ICI - InCar Internet																																	
CL-CLASS	216		Information	IC - Instrument cluster																																	
CL-CLASS	216		Information	DTA - Mbrace or TELEAID/GPS Box																																	
CL-CLASS	216		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	216		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	216		Information	AUDIO/COMAND																					V	V											
CL-CLASS	216		Information	ASSYST PLUS - PLUS Active Service System																																	
CL-CLASS	216		Information	ASSYST Active Service System																																	
CL-CLASS	216		Seat/Door	TLC/GTO - Garage door opener																																	
CL-CLASS	216		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	216		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	216		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	216		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	216		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	216		Seat/Door	DCM-FR - Door control module front right																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
CL-CLASS	216		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	216		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
CL-CLASS	216		Air Conditioning	AAC - Automatic air conditioning																																	
CL-CLASS	217		Drive	SCR - Selective catalytic reduction																																	
CL-CLASS	217		Drive	SG-EM - Power electronics																																	
CL-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
CL-CLASS	217		Drive	DTR - Distronic																																	
CL-CLASS	217		Drive	ISM - Intelligent servo module																																	
CL-CLASS	217		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
CL-CLASS	217		Drive	ETC - Electronic transmission control																																	
CL-CLASS	217		Drive	PTCU - Common powertrain controller																																	
CL-CLASS	217		Chassis	TPM - Tire pressure monitor																																	
CL-CLASS	217		Chassis	ABS/ESP - Electronic stability program																	V																
CL-CLASS	217		Chassis	ES - Electrical power steering																																	
CL-CLASS	217		Chassis	Suspension																																	
CL-CLASS	217		Chassis	EFB - Electric parking brake																																	
CL-CLASS	217		Information	TPAD - Touchpad																																	
CL-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio																																	
CL-CLASS	217		Information	360' - Camera																																	
CL-CLASS	217		Information	SOUND - Sound system																																	
CL-CLASS	217		Information	RFK - Backup camera																																	
CL-CLASS	217		Information	SGR - Radar sensors control unit																																	
CL-CLASS	217		Information	PTS - Parktronic system																																	
CL-CLASS	217		Information	NSA - Night View Assist																																	
CL-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
CL-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
CL-CLASS	217		Information	NBR-RF - Right front range radar																																	
CL-CLASS	217		Information	NBR-LF - Left front range radar																																	
CL-CLASS	217		Information	MFK - Multifunction camera																																	
CL-CLASS	217		Information	Head-up display																																	
CL-CLASS	217		Information	AUDIO/COMAND																																	
CL-CLASS	217		Information	ZAN - Audio/COMAND display																																	
CL-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit																																	
CL-CLASS	217		Information	KAB - Camera cover																																	
CL-CLASS	217		Information	IC - Instrument cluster																																	
CL-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box																															V		

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
CL-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection																																	
CL-CLASS	217		Body	SCM [MRM] - Steering column module																																	
CL-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
CL-CLASS	217		Body	AB - Airbag																																	
CL-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
CL-CLASS	217		Body	Headlamp-R - Headlamp control unit																																	
CL-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
CL-CLASS	217		Body	SG-AWF - Collision prevention assist																																	
CL-CLASS	217		Body	EZS/EIS - Electronic ignition lock																																	
CL-CLASS	217		Body	BNS/BMS - Battery sensor																																	
CL-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
CL-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
CL-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
CL-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
CL-CLASS	217		Seat/Door	HKS - Tailgate control																																	
CL-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
CL-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
CL-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control																																	
CL-CLASS	217		Seat/Door	DCM-FR - Door control module front right																																	
CL-CLASS	217		Seat/Door	DCM-FL - Door control module front left																																	
CL-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control																																	
CL-CLASS	217		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	170		Drive	ME/CDI/CNG - Engine control unit																							V										
SLK-CLASS	170		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	170		Drive	ESM - Electronic selector module																																	
SLK-CLASS	170		Chassis	ABS/ESP - Electronic stability program																									V	V							
SLK-CLASS	170		Chassis	VP - Vacuum pump brake booster																																	
SLK-CLASS	170		Chassis	BAS - Brake assist																																	
SLK-CLASS	170		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	170		Body	AB - Airbag																																	
SLK-CLASS	170		Information	IC - Instrument cluster																																	
SLK-CLASS	170		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	170		Information	AUDIO/COMAND																																	
SLK-CLASS	170		Air Conditioning	TSTH/STH - Stationary heater with remote control																														V		V	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
SLK-CLASS	170		Air Conditioning	AAC - Automatic air conditioning																																	
SLK-CLASS	171		Drive	ME/CDI/CNG - Engine control unit																V							V										
SLK-CLASS	171		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	171		Drive	ESM - Electronic selector module																																	
SLK-CLASS	171		Chassis	ABS/ESP - Electronic stability program																									V	V							
SLK-CLASS	171		Chassis	TPM - Tire pressure monitor																																	
SLK-CLASS	171		Body	WSS - Weight sensing system																																	
SLK-CLASS	171		Body	UCP - Upper control panel																																	
SLK-CLASS	171		Body	System diagnosis																																	
SLK-CLASS	171		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	171		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	171		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLK-CLASS	171		Body	OCP - Overhead control panel																								V									
SLK-CLASS	171		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	171		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	171		Body	CGW - Central gateway																																	
SLK-CLASS	171		Body	AB - Airbag																																	
SLK-CLASS	171		Information	TV - TV tuner																																	
SLK-CLASS	171		Information	SOUND - Sound system																																	
SLK-CLASS	171		Information	PTS - Parktronic system																																	
SLK-CLASS	171		Information	MIF/UCI - Media interface																																	
SLK-CLASS	171		Information	IC - Instrument cluster																																	
SLK-CLASS	171		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLK-CLASS	171		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	171		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SLK-CLASS	171		Information	AUDIO/COMAND																																	
SLK-CLASS	171		Information	ASSYST PLUS - PLUS Active Service System																																	
SLK-CLASS	171		Information	ASSYST Active Service System																																	
SLK-CLASS	171		Information	AGW - Audio gateway																																	
SLK-CLASS	171		Seat/Door	RVC/VDS - Convertible roof control																																	
SLK-CLASS	171		Seat/Door	HS - Seat heater																																	
SLK-CLASS	171		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	171		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	171		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	171		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	171		Air Conditioning	AAC - Automatic air conditioning																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
SLK-CLASS	172		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
SLK-CLASS	172		Drive	ETC - Electronic transmission control																																	
SLK-CLASS	172		Drive	ESM - Electronic selector module																																	
SLK-CLASS	172		Drive	DTR - Distronic																																	
SLK-CLASS	172		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLK-CLASS	172		Chassis	ABS/ESP - Electronic stability program						V																											
SLK-CLASS	172		Chassis	Suspension																																	
SLK-CLASS	172		Chassis	ES - Electrical power steering																																	
SLK-CLASS	172		Chassis	EFB - Electric parking brake																																	
SLK-CLASS	172		Chassis	TPM - Tire pressure monitor																										V							
SLK-CLASS	172		Body	SCM [MRM] - Steering column module																																	
SLK-CLASS	172		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLK-CLASS	172		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLK-CLASS	172		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLK-CLASS	172		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SLK-CLASS	172		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLK-CLASS	172		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLK-CLASS	172		Body	EZS/EIS - Electronic ignition lock																																	
SLK-CLASS	172		Body	CGW - Central gateway																																	
SLK-CLASS	172		Body	AB - Airbag																																	
SLK-CLASS	172		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SLK-CLASS	172		Information	ZAN - Audio/COMAND display																																	
SLK-CLASS	172		Information	TV - TV tuner																																	
SLK-CLASS	172		Information	SOUND - Sound system																																	
SLK-CLASS	172		Information	SGR - Radar sensors control unit																																	
SLK-CLASS	172		Information	MFK - Multifunction camera																																	
SLK-CLASS	172		Information	PTS - Parktronic system																																	
SLK-CLASS	172		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLK-CLASS	172		Information	NBR-RF - Right front range radar																																	
SLK-CLASS	172		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLK-CLASS	172		Information	NBR-LF - Left front range radar																																	
SLK-CLASS	172		Information	NAV - Navigation module																																	
SLK-CLASS	172		Information	MIF/UCI - Media interface																																	
SLK-CLASS	172		Information	IC - Instrument cluster																																	
SLK-CLASS	172		Information	DTA - Mbrace or TELEAID/GPS Box																																V	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
SLK-CLASS	172		Information	DAB/SDAR - Digital/Satellite radio																																	
SLK-CLASS	172		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLK-CLASS	172		Information	AUDIO/COMAND																					V	V											
SLK-CLASS	172		Seat/Door	RVC/VDS - Convertible roof control																																	
SLK-CLASS	172		Seat/Door	PSD/MSC - Sliding roof control																																	
SLK-CLASS	172		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLK-CLASS	172		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLK-CLASS	172		Seat/Door	DCM-FR - Door control module front right																																	
SLK-CLASS	172		Seat/Door	DCM-FL - Door control module front left																																	
SLK-CLASS	172		Air Conditioning	AAC - Automatic air conditioning														V																			
SL-CLASS	129		Drive	ME/CDI/CNG - Engine control unit																																	
SL-CLASS	129		Drive	ETC - Electronic transmission control																																	
SL-CLASS	129		Chassis	ABS/ESP - Electronic stability program																																	
SL-CLASS	129		Chassis	BAS - Brake assist																																	
SL-CLASS	129		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	129		Body	AB - Airbag																																	
SL-CLASS	129		Information	NAV - Navigation module																																	
SL-CLASS	129		Information	IC - Instrument cluster																																	
SL-CLASS	129		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	129		Information	AUDIO/COMAND																																	
SL-CLASS	129		Information	APS - Auto pilot system																																	
SL-CLASS	129		Air Conditioning	TSTH/STH - Stationary heater with remote control																														V			V
SL-CLASS	129		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	230		Drive	ME/CDI/CNG - Engine control unit																V							V										
SL-CLASS	230		Drive	ETC - Electronic transmission control																																	
SL-CLASS	230		Drive	ESM - Electronic selector module																																	
SL-CLASS	230		Drive	DTR - Distronic																																	
SL-CLASS	230		Drive	AMG DRIVE UNIT																																	
SL-CLASS	230		Chassis	ABS/ESP - Electronic stability program																									V	V							
SL-CLASS	230		Chassis	Suspension																																	
SL-CLASS	230		Chassis	SBC - Sensotronic Brake Control																																	
SL-CLASS	230		Chassis	PSE - Pneumatic system equipment																																	
SL-CLASS	230		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	230		Chassis	TPM - Tire pressure monitor																																	
SL-CLASS	230		Body	WSS - Weight sensing system																																	
SL-CLASS	230		Body	System diagnosis																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
SL-CLASS	230		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	230		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	230		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SL-CLASS	230		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	230		Body	OCP - Overhead control panel																																	
SL-CLASS	230		Body	LCP/HBF - Lower/Rear control panel																																	
SL-CLASS	230		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	230		Body	HSW/LRH - Steering wheel heater																																	
SL-CLASS	230		Body	Headlamp-R - Headlamp control unit																												V	V				
SL-CLASS	230		Body	Headlamp/Headlamp-L - Headlamp control unit																												V	V				
SL-CLASS	230		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	230		Body	CGW - Central gateway																																	
SL-CLASS	230		Body	BNS/BMS - Battery sensor																																	
SL-CLASS	230		Body	AB - Airbag																																	
SL-CLASS	230		Information	TV - TV tuner																																	
SL-CLASS	230		Information	SOUND - Sound system																																	
SL-CLASS	230		Information	PTS - Parktronic system																																	
SL-CLASS	230		Information	MIF/UCI - Media interface																																	
SL-CLASS	230		Information	IC - Instrument cluster																																	
SL-CLASS	230		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SL-CLASS	230		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	230		Information	CTEL/TEL - Cellular/Mobile telephone																																	
SL-CLASS	230		Information	AUDIO/COMAND																																	
SL-CLASS	230		Information	AGW - Audio gateway																																	
SL-CLASS	230		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	230		Seat/Door	OSB-FR - Multicontour backrest front right																																	
SL-CLASS	230		Seat/Door	OSB-FL - Multicontour backrest front left																																	
SL-CLASS	230		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	230		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	230		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	230		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	230		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
SL-CLASS	230		Air Conditioning	AAC - Automatic air conditioning																																	
SL-CLASS	231		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
SL-CLASS	231		Drive	ETC - Electronic transmission control																																	
SL-CLASS	231		Drive	ISM - Intelligent servo module																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
SL-CLASS	231		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SL-CLASS	231		Drive	DTR - Distronic																																	
SL-CLASS	231		Drive	DSI - Direct select interface																																	
SL-CLASS	231		Drive	AMG DRIVE UNIT																																	
SL-CLASS	231		Chassis	ABS/ESP - Electronic stability program						V																											
SL-CLASS	231		Chassis	Suspension																																	
SL-CLASS	231		Chassis	ES - Electrical power steering																																	
SL-CLASS	231		Chassis	EFB - Electric parking brake																																	
SL-CLASS	231		Chassis	FWGW - Chassis gateway																																	
SL-CLASS	231		Chassis	TPM - Tire pressure monitor																										V							
SL-CLASS	231		Body	SCM [MRM] - Steering column module																																	
SL-CLASS	231		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SL-CLASS	231		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SL-CLASS	231		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SL-CLASS	231		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
SL-CLASS	231		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SL-CLASS	231		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SL-CLASS	231		Body	EZS/EIS - Electronic ignition lock																																	
SL-CLASS	231		Body	CGW - Central gateway																																	
SL-CLASS	231		Body	AB - Airbag																																	
SL-CLASS	231		Information	Drive Kit Plus - Drive kit for iPhone(R)																																	
SL-CLASS	231		Information	ZAN - Audio/COMAND display																																	
SL-CLASS	231		Information	TV - TV tuner																																	
SL-CLASS	231		Information	SOUND - Sound system																																	
SL-CLASS	231		Information	SGR - Radar sensors control unit																																	
SL-CLASS	231		Information	RFK - Backup camera																																	
SL-CLASS	231		Information	MFK - Multifunction camera																																	
SL-CLASS	231		Information	PTS - Parktronic system																																	
SL-CLASS	231		Information	NSA - Night View Assist																																	
SL-CLASS	231		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SL-CLASS	231		Information	NBR-RF - Right front range radar																																	
SL-CLASS	231		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SL-CLASS	231		Information	NBR-LF - Left front range radar																																	
SL-CLASS	231		Information	MIF/UCI - Media interface																																	
SL-CLASS	231		Information	IC - Instrument cluster																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
SL-CLASS	231		Information	DTA - Mbrace or TELEAID/GPS Box																																V	
SL-CLASS	231		Information	DAB/SDAR - Digital/Satellite radio																																	
SL-CLASS	231		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SL-CLASS	231		Information	AUDIO/COMAND																					V	V											
SL-CLASS	231		Information	AMG Performance Media																																	
SL-CLASS	231		Seat/Door	RVC/VDS - Convertible roof control																																	
SL-CLASS	231		Seat/Door	PSD/MSC - Sliding roof control																																	
SL-CLASS	231		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SL-CLASS	231		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SL-CLASS	231		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
SL-CLASS	231		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
SL-CLASS	231		Seat/Door	DCM-FR - Door control module front right																																	
SL-CLASS	231		Seat/Door	DCM-FL - Door control module front left																																	
SL-CLASS	231		Air Conditioning	AAC - Automatic air conditioning														V																			
SLS-CLASS	197		Drive	PTCU - Common powertrain controller																																	
SLS-CLASS	197		Drive	ME/CDI/CNG - Engine control unit																V							V										
SLS-CLASS	197		Drive	ETC - Electronic transmission control																																	
SLS-CLASS	197		Drive	ISM - Intelligent servo module																																	
SLS-CLASS	197		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
SLS-CLASS	197		Drive	DSI - Direct select interface																																	
SLS-CLASS	197		Drive	AMG DRIVE UNIT																																	
SLS-CLASS	197		Chassis	ABS/ESP - Electronic stability program						V																											
SLS-CLASS	197		Chassis	Suspension																																	
SLS-CLASS	197		Chassis	ES - Electrical power steering																																	
SLS-CLASS	197		Chassis	EFB - Electric parking brake																																	
SLS-CLASS	197		Chassis	TPM - Tire pressure monitor																										V							
SLS-CLASS	197		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
SLS-CLASS	197		Body	CSHV - Crash sensor/high-voltage battery																																	
SLS-CLASS	197		Body	BNS/BMS - Battery sensor	V		V	V			V	V	V	V	V	V	V		V	V																	
SLS-CLASS	197		Body	WSS - Weight sensing system																																	
SLS-CLASS	197		Body	SCM [MRM] - Steering column module																																	
SLS-CLASS	197		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLS-CLASS	197		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLS-CLASS	197		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
SLS-CLASS	197		Body	HS/AIRSCARF - Seat heater/Air scarf system																																	
SLS-CLASS	197		Body	EZS/EIS - Electronic ignition lock																																	
SLS-CLASS	197		Body	CGW - Central gateway																																	
SLS-CLASS	197		Body	AB - Airbag																																	
SLS-CLASS	197		Information	MFK - Multifunction camera																																	
SLS-CLASS	197		Information	SGR - Radar sensors control unit																																	
SLS-CLASS	197		Information	ZAN - Audio/COMAND display																																	
SLS-CLASS	197		Information	SOUND - Sound system																																	
SLS-CLASS	197		Information	PTS - Parktronic system																																	
SLS-CLASS	197		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
SLS-CLASS	197		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
SLS-CLASS	197		Information	MIF/UCI - Media interface																																	
SLS-CLASS	197		Information	IC - Instrument cluster																																	
SLS-CLASS	197		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLS-CLASS	197		Information	DAB/SDAR - Digital/Satellite radio																																	
SLS-CLASS	197		Information	COU [ZBE] - Audio/COMAND operating unit																																	
SLS-CLASS	197		Information	AUDIO/COMAND																					V	V											
SLS-CLASS	197		Information	AMG Performance Media																																	
SLS-CLASS	197		Seat/Door	RVC/VDS - Convertible roof control																																	
SLS-CLASS	197		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
SLS-CLASS	197		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
SLS-CLASS	197		Seat/Door	DCM-FR - Door control module front right																																	
SLS-CLASS	197		Seat/Door	DCM-FL - Door control module front left																																	
SLS-CLASS	197		Air Conditioning	AAC - Automatic air conditioning														V																			
AMG GT	190		Drive	DTR - Distronic																																	
AMG GT	190		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
AMG GT	190		Drive	DSI - Direct select interface																																	
AMG GT	190		Drive	AMG DRIVE UNIT																																	
AMG GT	190		Drive	PTCU - Common powertrain controller																																	
AMG GT	190		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V																	
AMG GT	190		Drive	ETC - Electronic transmission control																																	
AMG GT	190		Chassis	TPM - Tire pressure monitor																																	
AMG GT	190		Chassis	Suspension																																	
AMG GT	190		Chassis	ABS/ESP - Electronic stability program						V																											
AMG GT	190		Chassis	EFB - Electric parking brake																																	
AMG GT	190		Information	TPAD - Touchpad																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
AMG GT	190		Information	DAB/SDAR - Digital/Satellite radio																																	
AMG GT	190		Information	SOUND - Sound system																																	
AMG GT	190		Information	RFK - Backup camera																																	
AMG GT	190		Information	PTS - Parktronic system																																	
AMG GT	190		Information	MFK - Multifunction camera																																	
AMG GT	190		Information	IC - Instrument cluster																																	
AMG GT	190		Information	NBR-LR/IRS-HLA - Left rear range radar																																	
AMG GT	190		Information	NBR-RR/IRS-HRA - Right rear range radar																																	
AMG GT	190		Information	AUDIO/COMAND																																	
AMG GT	190		Information	ZAN - Audio/COMAND display																																	
AMG GT	190		Information	COU [ZBE] - Audio/COMAND operating unit																																	
AMG GT	190		Information	DTA - Mbrace or TELEAID/GPS Box																															V		
AMG GT	190		Information	AMG Performance Media																																	
AMG GT	190		Body	SCM [MRM] - Steering column module																																	
AMG GT	190		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
AMG GT	190		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
AMG GT	190		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
AMG GT	190		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
AMG GT	190		Body	AB - Airbag																																	
AMG GT	190		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
AMG GT	190		Body	Headlamp-R - Headlamp control unit																																	
AMG GT	190		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
AMG GT	190		Body	SG-AWF - Collision prevention assist																																	
AMG GT	190		Body	EZS/EIS - Electronic ignition lock																																	
AMG GT	190		Body	CGW - Central gateway																																	
AMG GT	190		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
AMG GT	190		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
AMG GT	190		Seat/Door	DCM-FR - Door control module front right																																	
AMG GT	190		Seat/Door	DCM-FL - Door control module front left																																	
AMG GT	190		Air Conditioning	AAC - Automatic air conditioning														V																			
SLR-CLASS	199		Drive	ME/CDI/CNG - Engine control unit																																	
SLR-CLASS	199		Drive	ETC - Electronic transmission control																																	
SLR-CLASS	199		Drive	ESM - Electronic selector module																																	
SLR-CLASS	199		Chassis	ABS/ESP - Electronic stability program																																	
SLR-CLASS	199		Chassis	SBC - Sensotronic Brake Control																																	
SLR-CLASS	199		Chassis	TPM - Tire pressure monitor																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
SLR-CLASS	199		Body	WSS - Weight sensing system																																	
SLR-CLASS	199		Body	SCM [MRM] - Steering column module																																	
SLR-CLASS	199		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
SLR-CLASS	199		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
SLR-CLASS	199		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
SLR-CLASS	199		Body	OCP - Overhead control panel																																	
SLR-CLASS	199		Body	LCP/HBF - Lower/Rear control panel																																	
SLR-CLASS	199		Body	Headlamp-R - Headlamp control unit																																	
SLR-CLASS	199		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
SLR-CLASS	199		Body	EZS/EIS - Electronic ignition lock																																	
SLR-CLASS	199		Body	CGW - Central gateway																																	
SLR-CLASS	199		Body	BNS/BMS - Battery sensor																																	
SLR-CLASS	199		Body	AB - Airbag																																	
SLR-CLASS	199		Information	IC - Instrument cluster																																	
SLR-CLASS	199		Information	DTA - Mbrace or TELEAID/GPS Box																																	
SLR-CLASS	199		Information	AUDIO/COMAND																																	
SLR-CLASS	199		Seat/Door	DCM-FR - Door control module front right																																	
SLR-CLASS	199		Seat/Door	DCM-FL - Door control module front left																																	
SLR-CLASS	199		Air Conditioning	AAC - Automatic air conditioning																																	
MAYBACH	240		Drive	ME/CDI/CNG - Engine control unit																V							V											
MAYBACH	240		Drive	ETC - Electronic transmission control																																	
MAYBACH	240		Drive	ESM - Electronic selector module																																	
MAYBACH	240		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
MAYBACH	240		Drive	DTR - Distronic	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
MAYBACH	240		Chassis	ABS/ESP - Electronic stability program																																	
MAYBACH	240		Chassis	Suspension																																	
MAYBACH	240		Chassis	SBC - Sensotronic Brake Control																																	
MAYBACH	240		Chassis	TPM - Tire pressure monitor																																	
MAYBACH	240		Body	WSS - Weight sensing system																																	
MAYBACH	240		Body	System diagnosis																																	
MAYBACH	240		Body	SCM [MRM] - Steering column module																																	
MAYBACH	240		Body	HSW/LRH - Steering wheel heater																																	
MAYBACH	240		Body	Headlamp/Headlamp-L - Headlamp control unit																																	
MAYBACH	240		Body	AB - Airbag																																	
MAYBACH	240		Information	TV - TV tuner																																	
MAYBACH	240		Information	PTS - Parktronic system																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
MAYBACH	240		Information	DTA - Mbrace or TELEAID/GPS Box																																	
MAYBACH	240		Information	AGW - Audio gateway																																	
MAYBACH	240		Seat/Door	REDC/RWT - Rear end door control module																																	
MAYBACH	240		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All_Model(BETA)	16P Connector		Drive	SG-EM - Power electronics																																	
All_Model(BETA)	16P Connector		Drive	HFPM - Haptic accelerator pedal module																																	
All_Model(BETA)	16P Connector		Drive	ME/CDI/CNG - Engine control unit	V		V	V			V	V	V	V	V	V	V		V	V		V					V										
All_Model(BETA)	16P Connector		Drive	ETC - Electronic transmission control																																	
All_Model(BETA)	16P Connector		Drive	ESM - Electronic selector module																																	
All_Model(BETA)	16P Connector		Drive	VG - Transfer case																																	
All_Model(BETA)	16P Connector		Drive	VECU - Power monitoring control unit																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-B - Electric motor control unit B																																	
All_Model(BETA)	16P Connector		Drive	SG-EM-A - Electric motor control unit A																																	
All_Model(BETA)	16P Connector		Drive	SCR - Selective catalytic reduction																																	
All_Model(BETA)	16P Connector		Drive	PTCU - Common powertrain controller																																	
All_Model(BETA)	16P Connector		Drive	Natural gas control unit																																	
All_Model(BETA)	16P Connector		Drive	ISM - Intelligent servo module																																	
All_Model(BETA)	16P Connector		Drive	Hydrogen tank control unit																																	
All_Model(BETA)	16P Connector		Drive	HSG - Hybrid control unit																	V																
All_Model(BETA)	16P Connector		Drive	High-temperature coolant pump control unit																																	
All_Model(BETA)	16P Connector		Drive	Fuel cell control unit																																	
All_Model(BETA)	16P Connector		Drive	FSCU-R - Control unit fuel pump																																	
All_Model(BETA)	16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump																																	
All_Model(BETA)	16P Connector		Drive	EMPI - Electronic Motor Pump Inverter																																	
All_Model(BETA)	16P Connector		Drive	Electric drive control unit																																	
All_Model(BETA)	16P Connector		Drive	DTR - Distronic																																	
All_Model(BETA)	16P Connector		Drive	DSI - Direct select interface																																	
All_Model(BETA)	16P Connector		Drive	Compressed Natural Gas Control Module																																	
All_Model(BETA)	16P Connector		Drive	CC - Cruise control																																	
All_Model(BETA)	16P Connector		Drive	BSA - Belt-driven starter/alternator																																	
All_Model(BETA)	16P Connector		Drive	AMG DRIVE UNIT																																	
All_Model(BETA)	16P Connector		Drive	ACS - Automatic clutch system																																	
All_Model(BETA)	16P Connector		Chassis	ABS/ESP - Electronic stability program						V																		V	V								
All_Model(BETA)	16P Connector		Chassis	Suspension																																	
All_Model(BETA)	16P Connector		Chassis	SBC - Sensotronic Brake Control																																	
All_Model(BETA)	16P Connector		Chassis	PSE - Pneumatic system equipment																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
All_Model(BETA)	16P Connector		Chassis	HS/AIRSCARF - Seat heater/Air scarf system																																	
All_Model(BETA)	16P Connector		Chassis	HAQ - Interwheel differential lock at rear axle																																	
All_Model(BETA)	16P Connector		Chassis	FWGW - Chassis gateway																																	
All_Model(BETA)	16P Connector		Chassis	ES - Electrical power steering																																	
All_Model(BETA)	16P Connector		Chassis	EFB - Electric parking brake																																	
All_Model(BETA)	16P Connector		Chassis	BAS - Brake assist																																	
All_Model(BETA)	16P Connector		Chassis	VP - Vacuum pump brake booster																																	
All_Model(BETA)	16P Connector		Chassis	TPM - Tire pressure monitor																										V							
All_Model(BETA)	16P Connector		Body	SG-LML-VR - LED matrix of right front lamp unit																																	
All_Model(BETA)	16P Connector		Body	SG-LML-VL - LED matrix of left front lamp unit																																	
All_Model(BETA)	16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system																																	
All_Model(BETA)	16P Connector		Body	CSHV - Crash sensor/high-voltage battery																																	
All_Model(BETA)	16P Connector		Body	WSS - Weight sensing system																																	
All_Model(BETA)	16P Connector		Body	UCP - Upper control panel																																	
All_Model(BETA)	16P Connector		Body	System diagnosis																																	
All_Model(BETA)	16P Connector		Body	SG-DDW - DC/DC converter control unit																																	
All_Model(BETA)	16P Connector		Body	SG-AWF - Collision prevention assist																																	
All_Model(BETA)	16P Connector		Body	SCM [MRM] - Steering column module																																	
All_Model(BETA)	16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor																																	
All_Model(BETA)	16P Connector		Body	SAM-P- Passenger-side signal acquisition and actuation module																																	
All_Model(BETA)	16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side																																	
All_Model(BETA)	16P Connector		Body	RevETR-RF - Right front reversible emergency tensioning retractor																																	
All_Model(BETA)	16P Connector		Body	RevETR-LF - Left front reversible emergency tensioning retractor																																	
All_Model(BETA)	16P Connector		Body	RCM - Rear control module																																	
All_Model(BETA)	16P Connector		Body	OCP - Overhead control panel																								V						V			
All_Model(BETA)	16P Connector		Body	Multifunction control unit																																	
All_Model(BETA)	16P Connector		Body	LCP/HBF - Lower/Rear control panel																																	
All_Model(BETA)	16P Connector		Body	LAE [LAA] - Loading floor automatically extendable																																	
All_Model(BETA)	16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking																																	
All_Model(BETA)	16P Connector		Body	HSW/LRH - Steering wheel heater																																	
All_Model(BETA)	16P Connector		Body	Headlamp-R - Headlamp control unit																											V	V					
All_Model(BETA)	16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit																											V	V					
All_Model(BETA)	16P Connector		Body	EZS/EIS - Electronic ignition lock																																	
All_Model(BETA)	16P Connector		Body	CGW - Central gateway																																	
All_Model(BETA)	16P Connector		Body	BNS/BMS - Battery sensor																																	
All_Model(BETA)	16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection																																	

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
All_Model(BETA)	16P Connector		Body	AHE - Trailer recognition																																
All_Model(BETA)	16P Connector		Body	AB - Airbag																																
All_Model(BETA)	16P Connector		Body	AAM - All activity module																																
All_Model(BETA)	16P Connector		Information	TPAD - Touchpad																																
All_Model(BETA)	16P Connector		Information	Head-up display																																
All_Model(BETA)	16P Connector		Information	Drive Kit Plus - Drive kit for iPhone(R)																																
All_Model(BETA)	16P Connector		Information	KAB - Camera cover																																
All_Model(BETA)	16P Connector		Information	ZAN - Audio/COMAND display																																
All_Model(BETA)	16P Connector		Information	VCS - Voice control																																
All_Model(BETA)	16P Connector		Information	TV - TV tuner																																
All_Model(BETA)	16P Connector		Information	Tuner - Standard tuner																																
All_Model(BETA)	16P Connector		Information	Sound generator for exhaust system																																
All_Model(BETA)	16P Connector		Information	SOUND - Sound system																																
All_Model(BETA)	16P Connector		Information	SGR - Radar sensors control unit																																
All_Model(BETA)	16P Connector		Information	360' - Camera																																
All_Model(BETA)	16P Connector		Information	MFK - Multifunction camera																																
All_Model(BETA)	16P Connector		Information	RFK - Backup camera																																
All_Model(BETA)	16P Connector		Information	PTS - Parktronic system																																
All_Model(BETA)	16P Connector		Information	NSA - Night View Assist																																
All_Model(BETA)	16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar																																
All_Model(BETA)	16P Connector		Information	NBR-RF - Right front range radar																																
All_Model(BETA)	16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar																																
All_Model(BETA)	16P Connector		Information	NBR-LF - Left front range radar																																
All_Model(BETA)	16P Connector		Information	NAV - Navigation module																																
All_Model(BETA)	16P Connector		Information	MIF/UCI - Media interface																																
All_Model(BETA)	16P Connector		Information	ICI - InCar Internet																																
All_Model(BETA)	16P Connector		Information	IC - Instrument cluster																																
All_Model(BETA)	16P Connector		Information	DVD player																																
All_Model(BETA)	16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box																														V		
All_Model(BETA)	16P Connector		Information	D-FOR - Display in right rear passenger																																
All_Model(BETA)	16P Connector		Information	D-FOL - Display in left rear passenger																																
All_Model(BETA)	16P Connector		Information	DAB/SDAR - Digital/Satellite radio																																
All_Model(BETA)	16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone																																
All_Model(BETA)	16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit																																
All_Model(BETA)	16P Connector		Information	CM - Compass module																																
All_Model(BETA)	16P Connector		Information	AVE-H - Rear audio video unit																																

Series	Chassis	Type1	Type2	System	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding
All Model(BETA)	16P Connector		Information	AUDIO/COMAND																					V	V											
All Model(BETA)	16P Connector		Information	ASSYST PLUS - PLUS Active Service System																																	
All Model(BETA)	16P Connector		Information	ASSYST Active Service System																																	
All Model(BETA)	16P Connector		Information	APS - Auto pilot system																																	
All Model(BETA)	16P Connector		Information	AMG Performance Media																																	
All Model(BETA)	16P Connector		Information	AGW - Audio gateway																																	
All Model(BETA)	16P Connector		Seat/Door	Right rear ESE - Right electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	Left rear ESE - Left electrical seat adjustment																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-MR - Right center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TSG-ML - Left center door control unit																																	
All Model(BETA)	16P Connector		Seat/Door	TLC/GTO - Garage door opener																																	
All Model(BETA)	16P Connector		Seat/Door	RVC/VDS - Convertible roof control																																	
All Model(BETA)	16P Connector		Seat/Door	REDC/RWT - Rear end door control module																																	
All Model(BETA)	16P Connector		Seat/Door	PSD/MSC - Sliding roof control																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-R - Multicontour backrest rear																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FR - Multicontour backrest front right																																	
All Model(BETA)	16P Connector		Seat/Door	OSB-FL - Multicontour backrest front left																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HR - Rear right multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	MKL-HL - Rear left multicontour backrest																																	
All Model(BETA)	16P Connector		Seat/Door	HS - Seat heater																																	
All Model(BETA)	16P Connector		Seat/Door	HKS - Tailgate control																																	
All Model(BETA)	16P Connector		Seat/Door	ESA-R - Electric seat adjustment rear																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger																																	
All Model(BETA)	16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver																																	
All Model(BETA)	16P Connector		Seat/Door	ERA - Electric fold down backrest system																																	
All Model(BETA)	16P Connector		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat																																	
All Model(BETA)	16P Connector		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-RR - Door control module rear right																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-RL - Door control module rear left																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-FR - Door control module front right																																	
All Model(BETA)	16P Connector		Seat/Door	DCM-FL - Door control module front left																																	
All Model(BETA)	16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control																																	
All Model(BETA)	16P Connector		Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																	
All Model(BETA)	16P Connector		Air Conditioning	HBF - Rear control panel																																	
All Model(BETA)	16P Connector		Air Conditioning	HB - Heater booster																														V			V
All Model(BETA)	16P Connector		Air Conditioning	EKMK - Electric refrigerant compressor																																	
All Model(BETA)	16P Connector		Air Conditioning	AAC - Automatic air conditioning														V					V	V													

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
A-CLASS	68		Drive	ME/CDI/CNG - Engine control unit											
A-CLASS	68		Drive	ETC - Electronic transmission control											
A-CLASS	68		Drive	ESM - Electronic selector module											
A-CLASS	68		Drive	ACS - Automatic clutch system											
A-CLASS	68		Chassis	ABS/ESP - Electronic stability program											
A-CLASS	168		Chassis	ABS/ESP - Electronic stability program											
A-CLASS	168		Body	LCP/HBF - Lower/Rear control panel											
A-CLASS	168		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
A-CLASS	168		Body	ATA - ATA [EDW]/tow-away/interior protection											
A-CLASS	168		Body	AB - Airbag											
A-CLASS	168		Information	PTS - Parktronic system											
A-CLASS	168		Information	IC - Instrument cluster				V							
A-CLASS	168		Information	AUDIO/COMAND											
A-CLASS	168		Information	APS - Auto pilot system											
A-CLASS	168		Seat/Door	DCM-RR - Door control module rear right											
A-CLASS	168		Seat/Door	DCM-RL - Door control module rear left											
A-CLASS	168		Seat/Door	DCM-FR - Door control module front right											
A-CLASS	168		Seat/Door	DCM-FL - Door control module front left											
A-CLASS	168		Air Conditioning	TSTH/STH - Stationary heater with remote control											
A-CLASS	168		Air Conditioning	HB - Heater booster											
A-CLASS	168		Air Conditioning	AAC - Automatic air conditioning											
A-CLASS	169		Drive	ME/CDI/CNG - Engine control unit								V	V		
A-CLASS	169		Drive	ETC - Electronic transmission control											
A-CLASS	169		Drive	ESM - Electronic selector module											
A-CLASS	169		Drive	BSA - Belt-driven starter/alternator											
A-CLASS	169		Chassis	ABS/ESP - Electronic stability program											
A-CLASS	169		Chassis	ES - Electrical power steering											
A-CLASS	169		Body	SCM [MRM] - Steering column module											
A-CLASS	169		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
A-CLASS	169		Body	OCP - Overhead control panel					V						
A-CLASS	169		Body	Multifunction control unit											
A-CLASS	169		Body	Headlamp-R - Headlamp control unit											
A-CLASS	169		Body	Headlamp/Headlamp-L - Headlamp control unit											V
A-CLASS	169		Body	EZS/EIS - Electronic ignition lock											
A-CLASS	169		Body	CGW - Central gateway											
A-CLASS	169		Body	ATA - ATA [EDW]/tow-away/interior protection											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
A-CLASS	169		Body	AHE - Trailer recognition											
A-CLASS	169		Body	AB - Airbag											
A-CLASS	169		Information	SOUND - Sound system											
A-CLASS	169		Information	PTS - Parktronic system											
A-CLASS	169		Information	MIF/UCI - Media interface											
A-CLASS	169		Information	IC - Instrument cluster				V							
A-CLASS	169		Information	DAB/SDAR - Digital/Satellite radio											
A-CLASS	169		Information	CTEL/TEL - Cellular/Mobile telephone											
A-CLASS	169		Information	AUDIO/COMAND											
A-CLASS	169		Information	ASSYST PLUS - PLUS Active Service System											
A-CLASS	169		Information	ASSYST Active Service System											
A-CLASS	169		Information	AGW - Audio gateway											
A-CLASS	169		Seat/Door	DCM-RR - Door control module rear right											
A-CLASS	169		Seat/Door	DCM-RL - Door control module rear left											
A-CLASS	169		Seat/Door	DCM-FR - Door control module front right											
A-CLASS	169		Seat/Door	DCM-FL - Door control module front left											
A-CLASS	169		Air Conditioning	AAC - Automatic air conditioning											
A-CLASS	176		Drive	VG - Transfer case											
A-CLASS	176		Drive	ME/CDI/CNG - Engine control unit								V	V		
A-CLASS	176		Drive	ETC - Electronic transmission control											
A-CLASS	176		Drive	FSCU/FSCU-L - Control unit Fuel pump											
A-CLASS	176		Drive	DTR - Distronic											
A-CLASS	176		Drive	DSI - Direct select interface											
A-CLASS	176		Drive	PTCU - Common powertrain controller											
A-CLASS	176		Chassis	ABS/ESP - Electronic stability program											
A-CLASS	176		Chassis	ES - Electrical power steering											
A-CLASS	176		Chassis	EFB - Electric parking brake											
A-CLASS	176		Chassis	TPM - Tire pressure monitor						V	V				
A-CLASS	176		Body	SG-AWF - Collision prevention assist											
A-CLASS	176		Body	SCM [MRM] - Steering column module											
A-CLASS	176		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
A-CLASS	176		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
A-CLASS	176		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
A-CLASS	176		Body	Multifunction control unit											
A-CLASS	176		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
A-CLASS	176		Body	Headlamp/Headlamp-L - Headlamp control unit											V

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
A-CLASS	176		Body	EZS/EIS - Electronic ignition lock											
A-CLASS	176		Body	ATA - ATA [EDW]/tow-away/interior protection											
A-CLASS	176		Body	AHE - Trailer recognition											
A-CLASS	176		Body	AB - Airbag											
A-CLASS	176		Information	Drive Kit Plus - Drive kit for iPhone(R)											
A-CLASS	176		Information	ZAN - Audio/COMAND display											
A-CLASS	176		Information	TV - TV tuner											
A-CLASS	176		Information	SOUND - Sound system											
A-CLASS	176		Information	RFK - Backup camera											
A-CLASS	176		Information	MFK - Multifunction camera											
A-CLASS	176		Information	PTS - Parktronic system											
A-CLASS	176		Information	NBR-RR/IRS-HRA - Right rear range radar											
A-CLASS	176		Information	NBR-LR/IRS-HLA - Left rear range radar											
A-CLASS	176		Information	NAV - Navigation module											
A-CLASS	176		Information	MIF/UCI - Media interface											
A-CLASS	176		Information	IC - Instrument cluster											
A-CLASS	176		Information	DTA - Mbrace or TELEAID/GPS Box											
A-CLASS	176		Information	DAB/SDAR - Digital/Satellite radio											
A-CLASS	176		Information	COU [ZBE] - Audio/COMAND operating unit											
A-CLASS	176		Information	AUDIO/COMAND											
A-CLASS	176		Seat/Door	PSD/MSC - Sliding roof control											
A-CLASS	176		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
A-CLASS	176		Seat/Door	ESA Driver - Electric seat adjustment Driver											
A-CLASS	176		Seat/Door	DCM-FR - Door control module front right											
A-CLASS	176		Seat/Door	DCM-FL - Door control module front left											
A-CLASS	176		Air Conditioning	TSTH/STH - Stationary heater with remote control											
A-CLASS	176		Air Conditioning	AAC - Automatic air conditioning											
B-CLASS	245		Drive	ME/CDI/CNG - Engine control unit											
B-CLASS	245		Drive	ETC - Electronic transmission control											
B-CLASS	245		Drive	ESM - Electronic selector module											
B-CLASS	245		Drive	Hydrogen tank control unit											
B-CLASS	245		Drive	High-temperature coolant pump control unit											
B-CLASS	245		Drive	Fuel cell control unit											
B-CLASS	245		Drive	Electric drive control unit											
B-CLASS	245		Drive	Compressed Natural Gas Control Module											
B-CLASS	245		Drive	BSA - Belt-driven starter/alternator											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
B-CLASS	245		Drive	VECU - Power monitoring control unit											
B-CLASS	245		Chassis	ABS/ESP - Electronic stability program											
B-CLASS	245		Chassis	ES - Electrical power steering											
B-CLASS	245		Chassis	VP - Vacuum pump brake booster											
B-CLASS	245		Chassis	TPM - Tire pressure monitor											
B-CLASS	245		Body	WSS - Weight sensing system										V	
B-CLASS	245		Body	SG-DDW - DC/DC converter control unit											
B-CLASS	245		Body	SCM [MRM] - Steering column module											
B-CLASS	245		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
B-CLASS	245		Body	OCP - Overhead control panel					V						
B-CLASS	245		Body	Multifunction control unit											
B-CLASS	245		Body	Headlamp-R - Headlamp control unit											
B-CLASS	245		Body	Headlamp/Headlamp-L - Headlamp control unit											V
B-CLASS	245		Body	EZS/EIS - Electronic ignition lock											
B-CLASS	245		Body	CGW - Central gateway											
B-CLASS	245		Body	BNS/BMS - Battery sensor											
B-CLASS	245		Body	ATA - ATA [EDW]/tow-away/interior protection											
B-CLASS	245		Body	AHE - Trailer recognition											
B-CLASS	245		Body	AB - Airbag											
B-CLASS	245		Information	SOUND - Sound system											
B-CLASS	245		Information	PTS - Parktronic system											
B-CLASS	245		Information	NAV - Navigation module											
B-CLASS	245		Information	MIF/UCI - Media interface											
B-CLASS	245		Information	IC - Instrument cluster				V							
B-CLASS	245		Information	DTA - Mbrace or TELEAID/GPS Box											
B-CLASS	245		Information	DAB/SDAR - Digital/Satellite radio											
B-CLASS	245		Information	CTEL/TEL - Cellular/Mobile telephone											
B-CLASS	245		Information	CM - Compass module											
B-CLASS	245		Information	AUDIO/COMAND											
B-CLASS	245		Information	ASSYST PLUS - PLUS Active Service System											
B-CLASS	245		Information	ASSYST Active Service System											
B-CLASS	245		Information	AGW - Audio gateway											
B-CLASS	245		Seat/Door	DCM-RR - Door control module rear right											
B-CLASS	245		Seat/Door	DCM-RL - Door control module rear left											
B-CLASS	245		Seat/Door	DCM-FR - Door control module front right											
B-CLASS	245		Seat/Door	DCM-FL - Door control module front left											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
B-CLASS	245		Air Conditioning	EKMK - Electric refrigerant compressor											
B-CLASS	245		Air Conditioning	AAC - Automatic air conditioning											
B-CLASS	246		Drive	Compressed Natural Gas Control Module											
B-CLASS	246		Drive	VG - Transfer case											
B-CLASS	246		Drive	ME/CDI/CNG - Engine control unit								V	V		
B-CLASS	246		Drive	ETC - Electronic transmission control											
B-CLASS	246		Drive	FSCU/FSCU-L - Control unit Fuel pump											
B-CLASS	246		Drive	DTR - Distronic											
B-CLASS	246		Drive	PTCU - Common powertrain controller											
B-CLASS	246		Chassis	ABS/ESP - Electronic stability program											
B-CLASS	246		Chassis	ES - Electrical power steering											
B-CLASS	246		Chassis	EFB - Electric parking brake											
B-CLASS	246		Chassis	TPM - Tire pressure monitor						V	V				
B-CLASS	246		Body	BNS/BMS - Battery sensor											
B-CLASS	246		Body	SG-AWF - Collision prevention assist											
B-CLASS	246		Body	SCM [MRM] - Steering column module											
B-CLASS	246		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
B-CLASS	246		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
B-CLASS	246		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
B-CLASS	246		Body	Multifunction control unit											
B-CLASS	246		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
B-CLASS	246		Body	Headlamp-R - Headlamp control unit											
B-CLASS	246		Body	Headlamp/Headlamp-L - Headlamp control unit											V
B-CLASS	246		Body	EZS/EIS - Electronic ignition lock											
B-CLASS	246		Body	ATA - ATA [EDW]/tow-away/interior protection											
B-CLASS	246		Body	AHE - Trailer recognition											
B-CLASS	246		Body	AB - Airbag											
B-CLASS	246		Information	Sound generator for exhaust system											
B-CLASS	246		Information	Head-up display											
B-CLASS	246		Information	Drive Kit Plus - Drive kit for iPhone(R)											
B-CLASS	246		Information	ZAN - Audio/COMAND display											
B-CLASS	246		Information	TV - TV tuner											
B-CLASS	246		Information	SOUND - Sound system											
B-CLASS	246		Information	RFK - Backup camera											
B-CLASS	246		Information	MFK - Multifunction camera											
B-CLASS	246		Information	PTS - Parktronic system											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
B-CLASS	246		Information	NBR-RR/IRS-HRA - Right rear range radar											
B-CLASS	246		Information	NBR-LR/IRS-HLA - Left rear range radar											
B-CLASS	246		Information	NAV - Navigation module											
B-CLASS	246		Information	MIF/UCI - Media interface											
B-CLASS	246		Information	IC - Instrument cluster											
B-CLASS	246		Information	DTA - Mbrace or TELEAID/GPS Box											
B-CLASS	246		Information	DAB/SDAR - Digital/Satellite radio											
B-CLASS	246		Information	COU [ZBE] - Audio/COMAND operating unit											
B-CLASS	246		Information	AUDIO/COMAND											
B-CLASS	246		Seat/Door	PSD/MSC - Sliding roof control											
B-CLASS	246		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
B-CLASS	246		Seat/Door	ESA Driver - Electric seat adjustment Driver											
B-CLASS	246		Seat/Door	DCM-FR - Door control module front right											
B-CLASS	246		Seat/Door	DCM-FL - Door control module front left											
B-CLASS	246		Air Conditioning	TSTH/STH - Stationary heater with remote control											
B-CLASS	246		Air Conditioning	AAC - Automatic air conditioning											
C-CLASS	202		Drive	ME/CDI/CNG - Engine control unit											
C-CLASS	202		Drive	ETC - Electronic transmission control											
C-CLASS	202		Drive	ESM - Electronic selector module											
C-CLASS	202		Chassis	PSE - Pneumatic system equipment											
C-CLASS	202		Chassis	ABS/ESP - Electronic stability program											
C-CLASS	202		Chassis	VP - Vacuum pump brake booster											
C-CLASS	202		Chassis	BAS - Brake assist											
C-CLASS	202		Body	LCP/HBF - Lower/Rear control panel											
C-CLASS	202		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
C-CLASS	202		Body	EZS/EIS - Electronic ignition lock											
C-CLASS	202		Body	OCP - Overhead control panel											
C-CLASS	202		Body	AB - Airbag											
C-CLASS	202		Information	PTS - Parktronic system											
C-CLASS	202		Information	NAV - Navigation module											
C-CLASS	202		Information	IC - Instrument cluster				V							
C-CLASS	202		Information	DTA - Mbrace or TELEAID/GPS Box		V									
C-CLASS	202		Information	AUDIO/COMAND											
C-CLASS	202		Information	APS - Auto pilot system											
C-CLASS	202		Seat/Door	DCM-FR - Door control module front right											
C-CLASS	202		Seat/Door	DCM-FL - Door control module front left											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
C-CLASS	202		Seat/Door	DCM-RR - Door control module rear right											
C-CLASS	202		Seat/Door	DCM-RL - Door control module rear left											
C-CLASS	202		Air Conditioning	TSTH/STH - Stationary heater with remote control											
C-CLASS	202		Air Conditioning	HB - Heater booster											
C-CLASS	202		Air Conditioning	AAC - Automatic air conditioning											
C-CLASS	203		Drive	ME/CDI/CNG - Engine control unit											
C-CLASS	203		Drive	ETC - Electronic transmission control											
C-CLASS	203		Drive	ESM - Electronic selector module											
C-CLASS	203		Drive	DTR - Distronic											
C-CLASS	203		Chassis	ABS/ESP - Electronic stability program											
C-CLASS	203		Chassis	VP - Vacuum pump brake booster											
C-CLASS	203		Chassis	BAS - Brake assist											
C-CLASS	203		Body	WSS - Weight sensing system										V	
C-CLASS	203		Body	UCP - Upper control panel											
C-CLASS	203		Body	System diagnosis											
C-CLASS	203		Body	SCM [MRM] - Steering column module											
C-CLASS	203		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
C-CLASS	203		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
C-CLASS	203		Body	OCP - Overhead control panel					V						
C-CLASS	203		Body	Multifunction control unit											
C-CLASS	203		Body	LCP/HBF - Lower/Rear control panel											
C-CLASS	203		Body	Headlamp-R - Headlamp control unit											
C-CLASS	203		Body	Headlamp/Headlamp-L - Headlamp control unit											V
C-CLASS	203		Body	EZS/EIS - Electronic ignition lock											
C-CLASS	203		Body	CGW - Central gateway											
C-CLASS	203		Body	AHE - Trailer recognition											
C-CLASS	203		Body	AB - Airbag											
C-CLASS	203		Information	TV - TV tuner											
C-CLASS	203		Information	SOUND - Sound system											
C-CLASS	203		Information	PTS - Parktronic system											
C-CLASS	203		Information	NAV - Navigation module											
C-CLASS	203		Information	MIF/UCI - Media interface											
C-CLASS	203		Information	IC - Instrument cluster				V							
C-CLASS	203		Information	DTA - Mbrace or TELEAID/GPS Box		V									
C-CLASS	203		Information	DAB/SDAR - Digital/Satellite radio											
C-CLASS	203		Information	CTEL/TEL - Cellular/Mobile telephone											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
C-CLASS	203		Information	AUDIO/COMAND											
C-CLASS	203		Information	AGW - Audio gateway											
C-CLASS	203		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
C-CLASS	203		Seat/Door	ESA Driver - Electric seat adjustment Driver											
C-CLASS	203		Seat/Door	DCM-RR - Door control module rear right											
C-CLASS	203		Seat/Door	DCM-RL - Door control module rear left											
C-CLASS	203		Seat/Door	DCM-FR - Door control module front right											
C-CLASS	203		Seat/Door	DCM-FL - Door control module front left											
C-CLASS	203		Air Conditioning	TSTH/STH - Stationary heater with remote control											
C-CLASS	203		Air Conditioning	AAC - Automatic air conditioning											
C-CLASS	204		Drive	ME/CDI/CNG - Engine control unit								V	V		
C-CLASS	204		Drive	ETC - Electronic transmission control											
C-CLASS	204		Drive	ESM - Electronic selector module											
C-CLASS	204		Drive	SCR - Selective catalytic reduction			V								
C-CLASS	204		Drive	ISM - Intelligent servo module	V										
C-CLASS	204		Drive	FSCU-R - Control unit fuel pump											
C-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump											
C-CLASS	204		Drive	DTR - Distronic											
C-CLASS	204		Drive	AMG DRIVE UNIT											
C-CLASS	204		Drive	PTCU - Common powertrain controller											
C-CLASS	204		Chassis	ABS/ESP - Electronic stability program											
C-CLASS	204		Chassis	Suspension											
C-CLASS	204		Chassis	ES - Electrical power steering											
C-CLASS	204		Chassis	TPM - Tire pressure monitor						V	V				
C-CLASS	204		Body	WSS - Weight sensing system											
C-CLASS	204		Body	SCM [MRM] - Steering column module											
C-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
C-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
C-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
C-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
C-CLASS	204		Body	OCP - Overhead control panel											
C-CLASS	204		Body	Multifunction control unit											
C-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
C-CLASS	204		Body	Headlamp-R - Headlamp control unit											
C-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit											V
C-CLASS	204		Body	EZS/EIS - Electronic ignition lock											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
C-CLASS	204		Body	CGW - Central gateway											
C-CLASS	204		Body	AHE - Trailer recognition											
C-CLASS	204		Body	AB - Airbag											
C-CLASS	204		Information	Head-up display											
C-CLASS	204		Information	AVE-H - Rear audio video unit											
C-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)											
C-CLASS	204		Information	ZAN - Audio/COMAND display											
C-CLASS	204		Information	TV - TV tuner											
C-CLASS	204		Information	Sound generator for exhaust system											
C-CLASS	204		Information	SOUND - Sound system											
C-CLASS	204		Information	SGR - Radar sensors control unit											
C-CLASS	204		Information	360' - Camera											
C-CLASS	204		Information	MFK - Multifunction camera											
C-CLASS	204		Information	RFK - Backup camera											
C-CLASS	204		Information	PTS - Parktronic system											
C-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar											
C-CLASS	204		Information	NBR-RF - Right front range radar											
C-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar											
C-CLASS	204		Information	NBR-LF - Left front range radar											
C-CLASS	204		Information	NAV - Navigation module											
C-CLASS	204		Information	MIF/UCI - Media interface											
C-CLASS	204		Information	ICI - InCar Internet											
C-CLASS	204		Information	IC - Instrument cluster											
C-CLASS	204		Information	DVD player											
C-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box											
C-CLASS	204		Information	D-FOR - Display in right rear passenger											
C-CLASS	204		Information	D-FOL - Display in left rear passenger											
C-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio											
C-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone											
C-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit											
C-CLASS	204		Information	AUDIO/COMAND											
C-CLASS	204		Information	AMG Performance Media											
C-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control											
C-CLASS	204		Seat/Door	HKS - Tailgate control											
C-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
C-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
C-CLASS	204		Seat/Door	DCM-RR - Door control module rear right											
C-CLASS	204		Seat/Door	DCM-RL - Door control module rear left											
C-CLASS	204		Seat/Door	DCM-FR - Door control module front right											
C-CLASS	204		Seat/Door	DCM-FL - Door control module front left											
C-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control											
C-CLASS	204		Air Conditioning	AAC - Automatic air conditioning											
C-CLASS	205		Drive	SCR - Selective catalytic reduction			V								
C-CLASS	205		Drive	SG-EM - Power electronics											
C-CLASS	205		Drive	FSCU/FSCU-L - Control unit Fuel pump											
C-CLASS	205		Drive	HFPM - Haptic accelerator pedal module											
C-CLASS	205		Drive	DTR - Distronic											
C-CLASS	205		Drive	ISM - Intelligent servo module	V										
C-CLASS	205		Drive	ME/CDI/CNG - Engine control unit								V	V		
C-CLASS	205		Drive	ETC - Electronic transmission control											
C-CLASS	205		Drive	PTCU - Common powertrain controller											
C-CLASS	205		Chassis	TPM - Tire pressure monitor											
C-CLASS	205		Chassis	Suspension											
C-CLASS	205		Chassis	ABS/ESP - Electronic stability program											
C-CLASS	205		Chassis	ES - Electrical power steering											
C-CLASS	205		Chassis	EFB - Electric parking brake											
C-CLASS	205		Information	TPAD - Touchpad											
C-CLASS	205		Information	DAB/SDAR - Digital/Satellite radio											
C-CLASS	205		Information	360' - Camera											
C-CLASS	205		Information	Sound generator for exhaust system											
C-CLASS	205		Information	SOUND - Sound system											
C-CLASS	205		Information	RFK - Backup camera											
C-CLASS	205		Information	SGR - Radar sensors control unit											
C-CLASS	205		Information	PTS - Parktronic system											
C-CLASS	205		Information	NBR-RF - Right front range radar											
C-CLASS	205		Information	NBR-LF - Left front range radar											
C-CLASS	205		Information	MFK - Multifunction camera											
C-CLASS	205		Information	NBR-LR/IRS-HLA - Left rear range radar											
C-CLASS	205		Information	NBR-RR/IRS-HRA - Right rear range radar											
C-CLASS	205		Information	Head-up display											
C-CLASS	205		Information	AUDIO/COMAND											
C-CLASS	205		Information	ZAN - Audio/COMAND display											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
C-CLASS	205		Information	COU [ZBE] - Audio/COMAND operating unit											
C-CLASS	205		Information	KAB - Camera cover											
C-CLASS	205		Information	IC - Instrument cluster											
C-CLASS	205		Information	DTA - Mbrace or TELEAID/GPS Box											
C-CLASS	205		Body	ATA - ATA [EDW]/tow-away/interior protection											
C-CLASS	205		Body	AHE - Trailer recognition											
C-CLASS	205		Body	SCM [MRM] - Steering column module											
C-CLASS	205		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
C-CLASS	205		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
C-CLASS	205		Body	AB - Airbag											
C-CLASS	205		Body	Multifunction control unit											
C-CLASS	205		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
C-CLASS	205		Body	Headlamp-R - Headlamp control unit											
C-CLASS	205		Body	Headlamp/Headlamp-L - Headlamp control unit											V
C-CLASS	205		Body	SG-AWF - Collision prevention assist											
C-CLASS	205		Body	EZS/EIS - Electronic ignition lock											
C-CLASS	205		Body	BNS/BMS - Battery sensor											
C-CLASS	205		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
C-CLASS	205		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
C-CLASS	205		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
C-CLASS	205		Seat/Door	ESA Driver - Electric seat adjustment Driver											
C-CLASS	205		Seat/Door	PSD/MSC - Sliding roof control											
C-CLASS	205		Seat/Door	HKS - Tailgate control											
C-CLASS	205		Seat/Door	DCM-RR - Door control module rear right											
C-CLASS	205		Seat/Door	DCM-RL - Door control module rear left											
C-CLASS	205		Seat/Door	DCM-FR - Door control module front right											
C-CLASS	205		Seat/Door	DCM-FL - Door control module front left											
C-CLASS	205		Seat/Door	RVC/VDS - Convertible roof control											
C-CLASS	205		Air Conditioning	AAC - Automatic air conditioning											
E-CLASS	124		Drive	PMS/HFM/LH											
E-CLASS	124		Drive	ETC - Electronic transmission control											
E-CLASS	124		Drive	ISC - Idle speed control											
E-CLASS	124		Chassis	ABS/ESP - Electronic stability program											
E-CLASS	124		Body	AB - Airbag											
E-CLASS	210		Drive	ME/CDI/CNG - Engine control unit											
E-CLASS	210		Drive	ETC - Electronic transmission control											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
E-CLASS	210		Drive	ESM - Electronic selector module											
E-CLASS	210		Chassis	ABS/ESP - Electronic stability program											
E-CLASS	210		Chassis	VP - Vacuum pump brake booster											
E-CLASS	210		Chassis	PSE - Pneumatic system equipment											
E-CLASS	210		Chassis	BAS - Brake assist											
E-CLASS	210		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
E-CLASS	210		Body	OCP - Overhead control panel											
E-CLASS	210		Body	LCP/HBF - Lower/Rear control panel											
E-CLASS	210		Body	EZS/EIS - Electronic ignition lock											
E-CLASS	210		Body	AB - Airbag											
E-CLASS	210		Information	TV - TV tuner											
E-CLASS	210		Information	PTS - Parktronic system											
E-CLASS	210		Information	NAV - Navigation module											
E-CLASS	210		Information	IC - Instrument cluster				V							
E-CLASS	210		Information	DTA - Mbrace or TELEAID/GPS Box		V									
E-CLASS	210		Information	AUDIO/COMAND											
E-CLASS	210		Information	APS - Auto pilot system											
E-CLASS	210		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
E-CLASS	210		Seat/Door	ESA Driver - Electric seat adjustment Driver											
E-CLASS	210		Seat/Door	DCM-RR - Door control module rear right											
E-CLASS	210		Seat/Door	DCM-RL - Door control module rear left											
E-CLASS	210		Seat/Door	DCM-FR - Door control module front right											
E-CLASS	210		Seat/Door	DCM-FL - Door control module front left											
E-CLASS	210		Air Conditioning	TSTH/STH - Stationary heater with remote control											
E-CLASS	210		Air Conditioning	HB - Heater booster											
E-CLASS	210		Air Conditioning	AAC - Automatic air conditioning											
E-CLASS	211		Drive	ME/CDI/CNG - Engine control unit											
E-CLASS	211		Drive	ETC - Electronic transmission control											
E-CLASS	211		Drive	ESM - Electronic selector module											
E-CLASS	211		Drive	Natural gas control unit											
E-CLASS	211		Drive	FSCU/FSCU-L - Control unit Fuel pump											
E-CLASS	211		Drive	DTR - Distronic											
E-CLASS	211		Drive	Compressed Natural Gas Control Module											
E-CLASS	211		Chassis	ABS/ESP - Electronic stability program											
E-CLASS	211		Chassis	Suspension											
E-CLASS	211		Chassis	SBC - Sensotronic Brake Control											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
E-CLASS	211		Chassis	TPM - Tire pressure monitor											
E-CLASS	211		Body	WSS - Weight sensing system										V	
E-CLASS	211		Body	UCP - Upper control panel											
E-CLASS	211		Body	System diagnosis											
E-CLASS	211		Body	SCM [MRM] - Steering column module											
E-CLASS	211		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
E-CLASS	211		Body	SAM-P- Passenger-side signal acquisition and actuation module											
E-CLASS	211		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
E-CLASS	211		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
E-CLASS	211		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
E-CLASS	211		Body	OCP - Overhead control panel					V						
E-CLASS	211		Body	Multifunction control unit											
E-CLASS	211		Body	LCP/HBF - Lower/Rear control panel											
E-CLASS	211		Body	LAE [LAA] - Loading floor automatically extendable											
E-CLASS	211		Body	HSW/LRH - Steering wheel heater											
E-CLASS	211		Body	Headlamp-R - Headlamp control unit											
E-CLASS	211		Body	Headlamp/Headlamp-L - Headlamp control unit											V
E-CLASS	211		Body	EZS/EIS - Electronic ignition lock											
E-CLASS	211		Body	CGW - Central gateway											
E-CLASS	211		Body	BNS/BMS - Battery sensor											
E-CLASS	211		Body	AHE - Trailer recognition											
E-CLASS	211		Body	AB - Airbag											
E-CLASS	211		Information	TV - TV tuner											
E-CLASS	211		Information	SOUND - Sound system											
E-CLASS	211		Information	PTS - Parktronic system											
E-CLASS	211		Information	MIF/UCI - Media interface											
E-CLASS	211		Information	IC - Instrument cluster				V							
E-CLASS	211		Information	DTA - Mbrace or TELEAID/GPS Box											
E-CLASS	211		Information	DAB/SDAR - Digital/Satellite radio											
E-CLASS	211		Information	CTEL/TEL - Cellular/Mobile telephone											
E-CLASS	211		Information	AUDIO/COMAND											
E-CLASS	211		Information	ASSYST PLUS - PLUS Active Service System											
E-CLASS	211		Information	ASSYST Active Service System											
E-CLASS	211		Information	AGW - Audio gateway											
E-CLASS	211		Seat/Door	REDC/RWT - Rear end door control module											
E-CLASS	211		Seat/Door	HS - Seat heater											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
E-CLASS	211		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
E-CLASS	211		Seat/Door	ESA Driver - Electric seat adjustment Driver											
E-CLASS	211		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
E-CLASS	211		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
E-CLASS	211		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
E-CLASS	211		Seat/Door	DCM-RR - Door control module rear right											
E-CLASS	211		Seat/Door	DCM-RL - Door control module rear left											
E-CLASS	211		Seat/Door	DCM-FR - Door control module front right											
E-CLASS	211		Seat/Door	DCM-FL - Door control module front left											
E-CLASS	211		Air Conditioning	TSTH/STH - Stationary heater with remote control											
E-CLASS	211		Air Conditioning	AAC - Automatic air conditioning											
E-CLASS	207		Drive	SG-EM - Power electronics											
E-CLASS	207		Drive	SCR - Selective catalytic reduction			V								
E-CLASS	207		Drive	ME/CDI/CNG - Engine control unit								V	V		
E-CLASS	207		Drive	ETC - Electronic transmission control											
E-CLASS	207		Drive	ESM - Electronic selector module											
E-CLASS	207		Drive	ISM - Intelligent servo module	V										
E-CLASS	207		Drive	FSCU/FSCU-L - Control unit Fuel pump											
E-CLASS	207		Drive	DTR - Distronic											
E-CLASS	207		Drive	DSI - Direct select interface											
E-CLASS	207		Drive	AMG DRIVE UNIT											
E-CLASS	207		Chassis	ABS/ESP - Electronic stability program											
E-CLASS	207		Chassis	Suspension											
E-CLASS	207		Chassis	ES - Electrical power steering											
E-CLASS	207		Chassis	FWGW - Chassis gateway											
E-CLASS	207		Chassis	TPM - Tire pressure monitor						V	V				
E-CLASS	207		Body	BNS/BMS - Battery sensor											
E-CLASS	207		Body	WSS - Weight sensing system											
E-CLASS	207		Body	SG-AWF - Collision prevention assist											
E-CLASS	207		Body	SCM [MRM] - Steering column module											
E-CLASS	207		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
E-CLASS	207		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
E-CLASS	207		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
E-CLASS	207		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
E-CLASS	207		Body	Multifunction control unit											
E-CLASS	207		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
E-CLASS	207		Body	HS/AIRSCARF - Seat heater/Air scarf system											
E-CLASS	207		Body	Headlamp-R - Headlamp control unit											
E-CLASS	207		Body	Headlamp/Headlamp-L - Headlamp control unit											V
E-CLASS	207		Body	EZS/EIS - Electronic ignition lock											
E-CLASS	207		Body	CGW - Central gateway											
E-CLASS	207		Body	AHE - Trailer recognition											
E-CLASS	207		Body	AB - Airbag											
E-CLASS	207		Information	NBR-RF - Right front range radar											
E-CLASS	207		Information	NBR-LF - Left front range radar											
E-CLASS	207		Information	AVE-H - Rear audio video unit											
E-CLASS	207		Information	Drive Kit Plus - Drive kit for iPhone(R)											
E-CLASS	207		Information	ZAN - Audio/COMAND display											
E-CLASS	207		Information	TV - TV tuner											
E-CLASS	207		Information	SOUND - Sound system											
E-CLASS	207		Information	SGR - Radar sensors control unit											
E-CLASS	207		Information	360' - Camera											
E-CLASS	207		Information	MFK - Multifunction camera											
E-CLASS	207		Information	RFK - Backup camera											
E-CLASS	207		Information	PTS - Parktronic system											
E-CLASS	207		Information	NSA - Night View Assist											
E-CLASS	207		Information	NBR-RR/IRS-HRA - Right rear range radar											
E-CLASS	207		Information	NBR-LR/IRS-HLA - Left rear range radar											
E-CLASS	207		Information	NAV - Navigation module											
E-CLASS	207		Information	MIF/UCI - Media interface											
E-CLASS	207		Information	ICI - InCar Internet											
E-CLASS	207		Information	IC - Instrument cluster											
E-CLASS	207		Information	DVD player											
E-CLASS	207		Information	DTA - Mbrace or TELEAID/GPS Box											
E-CLASS	207		Information	D-FOR - Display in right rear passenger											
E-CLASS	207		Information	D-FOL - Display in left rear passenger											
E-CLASS	207		Information	DAB/SDAR - Digital/Satellite radio											
E-CLASS	207		Information	CTEL/TEL - Cellular/Mobile telephone											
E-CLASS	207		Information	COU [ZBE] - Audio/COMAND operating unit											
E-CLASS	207		Information	AUDIO/COMAND											
E-CLASS	207		Seat/Door	RVC/VDS - Convertible roof control											
E-CLASS	207		Seat/Door	PSD/MSC - Sliding roof control											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
E-CLASS	207		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
E-CLASS	207		Seat/Door	ESA Driver - Electric seat adjustment Driver											
E-CLASS	207		Seat/Door	DCM-FR - Door control module front right											
E-CLASS	207		Seat/Door	DCM-FL - Door control module front left											
E-CLASS	207		Air Conditioning	EKMK - Electric refrigerant compressor											
E-CLASS	207		Air Conditioning	TSTH/STH - Stationary heater with remote control											
E-CLASS	207		Air Conditioning	AAC - Automatic air conditioning											
E-CLASS	212		Drive	SG-EM - Power electronics											
E-CLASS	212		Drive	Compressed Natural Gas Control Module											
E-CLASS	212		Drive	ME/CDI/CNG - Engine control unit								V	V		
E-CLASS	212		Drive	ETC - Electronic transmission control											
E-CLASS	212		Drive	ESM - Electronic selector module											
E-CLASS	212		Drive	SCR - Selective catalytic reduction			V								
E-CLASS	212		Drive	ISM - Intelligent servo module	V										
E-CLASS	212		Drive	FSCU/FSCU-L - Control unit Fuel pump											
E-CLASS	212		Drive	DTR - Distronic											
E-CLASS	212		Drive	DSI - Direct select interface											
E-CLASS	212		Drive	AMG DRIVE UNIT											
E-CLASS	212		Chassis	ABS/ESP - Electronic stability program											
E-CLASS	212		Chassis	Suspension											
E-CLASS	212		Chassis	ES - Electrical power steering											
E-CLASS	212		Chassis	FWGW - Chassis gateway											
E-CLASS	212		Chassis	TPM - Tire pressure monitor						V	V				
E-CLASS	212		Body	BNS/BMS - Battery sensor											
E-CLASS	212		Body	WSS - Weight sensing system											
E-CLASS	212		Body	SG-AWF - Collision prevention assist											
E-CLASS	212		Body	SCM [MRM] - Steering column module											
E-CLASS	212		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
E-CLASS	212		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
E-CLASS	212		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
E-CLASS	212		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
E-CLASS	212		Body	OCP - Overhead control panel											
E-CLASS	212		Body	Multifunction control unit											
E-CLASS	212		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
E-CLASS	212		Body	HSW/LRH - Steering wheel heater											
E-CLASS	212		Body	HS/AIRSCARF - Seat heater/Air scarf system											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
E-CLASS	212		Body	Headlamp-R - Headlamp control unit											
E-CLASS	212		Body	Headlamp/Headlamp-L - Headlamp control unit											V
E-CLASS	212		Body	EZS/EIS - Electronic ignition lock											
E-CLASS	212		Body	CGW - Central gateway											
E-CLASS	212		Body	AHE - Trailer recognition											
E-CLASS	212		Body	AB - Airbag											
E-CLASS	212		Information	Head-up display											
E-CLASS	212		Information	AVE-H - Rear audio video unit											
E-CLASS	212		Information	Drive Kit Plus - Drive kit for iPhone(R)											
E-CLASS	212		Information	ZAN - Audio/COMAND display											
E-CLASS	212		Information	TV - TV tuner											
E-CLASS	212		Information	SOUND - Sound system											
E-CLASS	212		Information	SGR - Radar sensors control unit											
E-CLASS	212		Information	360' - Camera											
E-CLASS	212		Information	MFK - Multifunction camera											
E-CLASS	212		Information	RFK - Backup camera											
E-CLASS	212		Information	PTS - Parktronic system											
E-CLASS	212		Information	NSA - Night View Assist											
E-CLASS	212		Information	NBR-RR/IRS-HRA - Right rear range radar											
E-CLASS	212		Information	NBR-RF - Right front range radar											
E-CLASS	212		Information	NBR-LR/IRS-HLA - Left rear range radar											
E-CLASS	212		Information	NBR-LF - Left front range radar											
E-CLASS	212		Information	NAV - Navigation module											
E-CLASS	212		Information	MIF/UCI - Media interface											
E-CLASS	212		Information	ICI - InCar Internet											
E-CLASS	212		Information	IC - Instrument cluster											
E-CLASS	212		Information	DVD player											
E-CLASS	212		Information	DTA - Mbrace or TELEAID/GPS Box											
E-CLASS	212		Information	D-FOR - Display in right rear passenger											
E-CLASS	212		Information	D-FOL - Display in left rear passenger											
E-CLASS	212		Information	DAB/SDAR - Digital/Satellite radio											
E-CLASS	212		Information	CTEL/TEL - Cellular/Mobile telephone											
E-CLASS	212		Information	COU [ZBE] - Audio/COMAND operating unit											
E-CLASS	212		Information	AUDIO/COMAND											
E-CLASS	212		Seat/Door	PSD/MSC - Sliding roof control											
E-CLASS	212		Seat/Door	HKS - Tailgate control											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
E-CLASS	212		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
E-CLASS	212		Seat/Door	ESA Driver - Electric seat adjustment Driver											
E-CLASS	212		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
E-CLASS	212		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
E-CLASS	212		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
E-CLASS	212		Seat/Door	DCM-RR - Door control module rear right											
E-CLASS	212		Seat/Door	DCM-RL - Door control module rear left											
E-CLASS	212		Seat/Door	DCM-FR - Door control module front right											
E-CLASS	212		Seat/Door	DCM-FL - Door control module front left											
E-CLASS	212		Air Conditioning	EKMK - Electric refrigerant compressor											
E-CLASS	212		Air Conditioning	TSTH/STH - Stationary heater with remote control											
E-CLASS	212		Air Conditioning	AAC - Automatic air conditioning											
E-CLASS	213		Drive	SCR - Selective catalytic reduction			V								
E-CLASS	213		Drive	DTR - Distronic											
E-CLASS	213		Drive	FSCU/FSCU-L - Control unit Fuel pump											
E-CLASS	213		Drive	HFPM - Haptic accelerator pedal module											
E-CLASS	213		Drive	AMG DRIVE UNIT											
E-CLASS	213		Drive	PTCU - Common powertrain controller											
E-CLASS	213		Drive	ME/CDI/CNG - Engine control unit								V	V		
E-CLASS	213		Drive	ETC - Electronic transmission control											
E-CLASS	213		Chassis	TPM - Tire pressure monitor											
E-CLASS	213		Chassis	AIRMATIC PLUS											
E-CLASS	213		Chassis	ES - Electrical power steering											
E-CLASS	213		Chassis	Suspension											
E-CLASS	213		Chassis	ABS/ESP - Electronic stability program											
E-CLASS	213		Body	MTAS - Mobile phone cradle											
E-CLASS	213		Body	AHE - Trailer recognition											
E-CLASS	213		Body	SCM [MRM] - Steering column module											
E-CLASS	213		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
E-CLASS	213		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
E-CLASS	213		Body	SG-LML-VR - LED matrix of right front lamp unit											
E-CLASS	213		Body	SG-LML-VL - LED matrix of left front lamp unit											
E-CLASS	213		Body	AB - Airbag											
E-CLASS	213		Body	OCP - Overhead control panel											
E-CLASS	213		Body	Multifunction control unit											
E-CLASS	213		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
E-CLASS	213		Body	SG-DDW - DC/DC converter control unit											
E-CLASS	213		Body	Headlamp-R - Headlamp control unit											
E-CLASS	213		Body	Headlamp/Headlamp-L - Headlamp control unit											V
E-CLASS	213		Body	SG-AWF - Collision prevention assist											
E-CLASS	213		Body	EZS/EIS - Electronic ignition lock											
E-CLASS	213		Body	BNS/BMS - Battery sensor											
E-CLASS	213		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
E-CLASS	213		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
E-CLASS	213		Body	AML - Ambiance light											
E-CLASS	213		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
E-CLASS	213		Seat/Door	ESA Driver - Electric seat adjustment Driver											
E-CLASS	213		Seat/Door	Right rear ESE - Right electrical seat adjustment											
E-CLASS	213		Seat/Door	Left rear ESE - Left electrical seat adjustment											
E-CLASS	213		Seat/Door	PSD/MSC - Sliding roof control											
E-CLASS	213		Seat/Door	HKS - Tailgate control											
E-CLASS	213		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
E-CLASS	213		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat											
E-CLASS	213		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat											
E-CLASS	213		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
E-CLASS	213		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
E-CLASS	213		Seat/Door	DCM-RR - Door control module rear right											
E-CLASS	213		Seat/Door	DCM-RL - Door control module rear left											
E-CLASS	213		Seat/Door	DCM-FR - Door control module front right											
E-CLASS	213		Seat/Door	DCM-FL - Door control module front left											
E-CLASS	213		Seat/Door	RVC/VDS - Convertible roof control											
E-CLASS	213		Information	DAB/SDAR - Digital/Satellite radio											
E-CLASS	213		Information	TPAD - Touchpad											
E-CLASS	213		Information	Sound generator for exhaust system											
E-CLASS	213		Information	SOUND - Sound system											
E-CLASS	213		Information	RFK - Backup camera											
E-CLASS	213		Information	PTS - Parktronic system											
E-CLASS	213		Information	MFK - Multifunction camera											
E-CLASS	213		Information	NBR-LR/IRS-HLA - Left rear range radar											
E-CLASS	213		Information	NBR-RR/IRS-HRA - Right rear range radar											
E-CLASS	213		Information	SGR - Radar sensors control unit											
E-CLASS	213		Information	IC - Instrument cluster											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
E-CLASS	213		Information	Head-up display											
E-CLASS	213		Information	AUDIO/COMAND											
E-CLASS	213		Information	DTA - Mbrace or TELEAID/GPS Box											
E-CLASS	213		Information	ZAN - Audio/COMAND display											
E-CLASS	213		Information	COU [ZBE] - Audio/COMAND operating unit											
E-CLASS	213		Air Conditioning	AAC - Automatic air conditioning											
S-CLASS	140		Drive	ASF											
S-CLASS	140		Drive	ERE											
S-CLASS	140		Drive	ME1LI											
S-CLASS	140		Drive	ME1RE											
S-CLASS	140		Drive	HFM/ME2/LH											
S-CLASS	140		Drive	ETC - Electronic transmission control											
S-CLASS	140		Drive	ISC - Idle speed control											
S-CLASS	140		Chassis	ABS/ESP - Electronic stability program											
S-CLASS	140		Chassis	BAS - Brake assist											
S-CLASS	140		Body	PSE - Pneumatic system equipment											
S-CLASS	140		Body	AB - Airbag											
S-CLASS	140		Information	PTS - Parktronic system											
S-CLASS	140		Information	IC - Instrument cluster											
S-CLASS	140		Air Conditioning	AAC - Automatic air conditioning											
S-CLASS	220		Drive	ME/CDI/CNG - Engine control unit											
S-CLASS	220		Drive	ETC - Electronic transmission control											
S-CLASS	220		Drive	ESM - Electronic selector module											
S-CLASS	220		Drive	DTR - Distronic											
S-CLASS	220		Chassis	TPM - Tire pressure monitor											
S-CLASS	220		Chassis	Suspension											
S-CLASS	220		Chassis	PSE - Pneumatic system equipment											
S-CLASS	220		Chassis	ABS/ESP - Electronic stability program											
S-CLASS	220		Body	UCP - Upper control panel											
S-CLASS	220		Body	System diagnosis											
S-CLASS	220		Body	SCM [MRM] - Steering column module											
S-CLASS	220		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
S-CLASS	220		Body	SAM-P- Passenger-side signal acquisition and actuation module											
S-CLASS	220		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
S-CLASS	220		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
S-CLASS	220		Body	RevETR-LF - Left front reversible emergency tensioning retractor											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
S-CLASS	220		Body	OCP - Overhead control panel											
S-CLASS	220		Body	Multifunction control unit											
S-CLASS	220		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
S-CLASS	220		Body	HSW/LRH - Steering wheel heater											
S-CLASS	220		Body	Headlamp-R - Headlamp control unit											
S-CLASS	220		Body	Headlamp/Headlamp-L - Headlamp control unit											V
S-CLASS	220		Body	EZS/EIS - Electronic ignition lock											
S-CLASS	220		Body	CGW - Central gateway											
S-CLASS	220		Body	AHE - Trailer recognition											
S-CLASS	220		Body	AB - Airbag											
S-CLASS	220		Information	TV - TV tuner											
S-CLASS	220		Information	PTS - Parktronic system											
S-CLASS	220		Information	NAV - Navigation module											
S-CLASS	220		Information	IC - Instrument cluster				V							
S-CLASS	220		Information	DTA - Mbrace or TELEAID/GPS Box		V									
S-CLASS	220		Information	AUDIO/COMAND											
S-CLASS	220		Information	AGW - Audio gateway											
S-CLASS	220		Seat/Door	OSB-R - Multicontour backrest rear											
S-CLASS	220		Seat/Door	OSB-FL - Multicontour backrest front left											
S-CLASS	220		Seat/Door	ESA-R - Electric seat adjustment rear											
S-CLASS	220		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
S-CLASS	220		Seat/Door	ESA Driver - Electric seat adjustment Driver											
S-CLASS	220		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
S-CLASS	220		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
S-CLASS	220		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
S-CLASS	220		Seat/Door	DCM-RR - Door control module rear right											
S-CLASS	220		Seat/Door	DCM-RL - Door control module rear left											
S-CLASS	220		Seat/Door	DCM-FR - Door control module front right											
S-CLASS	220		Seat/Door	DCM-FL - Door control module front left											
S-CLASS	220		Air Conditioning	TSTH/STH - Stationary heater with remote control											
S-CLASS	220		Air Conditioning	KBE-H/REAR AC - Rear air conditioning											
S-CLASS	220		Air Conditioning	AAC - Automatic air conditioning											
S-CLASS	221		Drive	ME/CDI/CNG - Engine control unit								V	V		
S-CLASS	221		Drive	ETC - Electronic transmission control											
S-CLASS	221		Drive	SCR - Selective catalytic reduction			V								
S-CLASS	221		Drive	ISM - Intelligent servo module	V										

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
S-CLASS	221		Drive	HSG - Hybrid control unit											
S-CLASS	221		Drive	FSCU/FSCU-L - Control unit Fuel pump											
S-CLASS	221		Drive	DTR - Distronic											
S-CLASS	221		Chassis	ABS/ESP - Electronic stability program											
S-CLASS	221		Chassis	Suspension											
S-CLASS	221		Chassis	ES - Electrical power steering											
S-CLASS	221		Chassis	EFB - Electric parking brake											
S-CLASS	221		Chassis	TPM - Tire pressure monitor						V	V				
S-CLASS	221		Body	WSS - Weight sensing system											
S-CLASS	221		Body	UCP - Upper control panel											
S-CLASS	221		Body	System diagnosis											
S-CLASS	221		Body	SG-DDW - DC/DC converter control unit											
S-CLASS	221		Body	SCM [MRM] - Steering column module											
S-CLASS	221		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
S-CLASS	221		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
S-CLASS	221		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
S-CLASS	221		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
S-CLASS	221		Body	OCP - Overhead control panel											
S-CLASS	221		Body	Multifunction control unit											
S-CLASS	221		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
S-CLASS	221		Body	Headlamp-R - Headlamp control unit											
S-CLASS	221		Body	Headlamp/Headlamp-L - Headlamp control unit											V
S-CLASS	221		Body	EZS/EIS - Electronic ignition lock											
S-CLASS	221		Body	CGW - Central gateway											
S-CLASS	221		Body	BNS/BMS - Battery sensor											
S-CLASS	221		Body	AHE - Trailer recognition											
S-CLASS	221		Body	AB - Airbag											
S-CLASS	221		Information	ZAN - Audio/COMAND display											
S-CLASS	221		Information	VCS - Voice control											
S-CLASS	221		Information	TV - TV tuner											
S-CLASS	221		Information	Tuner - Standard tuner											
S-CLASS	221		Information	SOUND - Sound system											
S-CLASS	221		Information	SGR - Radar sensors control unit											
S-CLASS	221		Information	MFK - Multifunction camera											
S-CLASS	221		Information	RFK - Backup camera											
S-CLASS	221		Information	PTS - Parktronic system											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
S-CLASS	221		Information	NSA - Night View Assist											
S-CLASS	221		Information	NBR-LF - Left front range radar											
S-CLASS	221		Information	NAV - Navigation module											
S-CLASS	221		Information	MIF/UCI - Media interface											
S-CLASS	221		Information	ICI - InCar Internet											
S-CLASS	221		Information	IC - Instrument cluster											
S-CLASS	221		Information	DVD player											
S-CLASS	221		Information	DTA - Mbrace or TELEAID/GPS Box											
S-CLASS	221		Information	D-FOR - Display in right rear passenger											
S-CLASS	221		Information	D-FOL - Display in left rear passenger											
S-CLASS	221		Information	DAB/SDAR - Digital/Satellite radio											
S-CLASS	221		Information	COU [ZBE] - Audio/COMAND operating unit											
S-CLASS	221		Information	AVE-H - Rear audio video unit											
S-CLASS	221		Information	AUDIO/COMAND											
S-CLASS	221		Information	ASSYST PLUS - PLUS Active Service System											
S-CLASS	221		Information	ASSYST Active Service System											
S-CLASS	221		Seat/Door	TSG-MR - Right center door control unit											
S-CLASS	221		Seat/Door	TSG-ML - Left center door control unit											
S-CLASS	221		Seat/Door	TLC/GTO - Garage door opener											
S-CLASS	221		Seat/Door	PSD/MSC - Sliding roof control											
S-CLASS	221		Seat/Door	MKL-HR - Rear right multicontour backrest											
S-CLASS	221		Seat/Door	MKL-HL - Rear left multicontour backrest											
S-CLASS	221		Seat/Door	HKS - Tailgate control											
S-CLASS	221		Seat/Door	ESA-R - Electric seat adjustment rear											
S-CLASS	221		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
S-CLASS	221		Seat/Door	ESA Driver - Electric seat adjustment Driver											
S-CLASS	221		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
S-CLASS	221		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
S-CLASS	221		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
S-CLASS	221		Seat/Door	DCM-RR - Door control module rear right											
S-CLASS	221		Seat/Door	DCM-RL - Door control module rear left											
S-CLASS	221		Seat/Door	DCM-FR - Door control module front right											
S-CLASS	221		Seat/Door	DCM-FL - Door control module front left											
S-CLASS	221		Air Conditioning	TSTH/STH - Stationary heater with remote control											
S-CLASS	221		Air Conditioning	KBE-H/REAR AC - Rear air conditioning											
S-CLASS	221		Air Conditioning	HBF - Rear control panel											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
S-CLASS	221		Air Conditioning	AAC - Automatic air conditioning											
S-CLASS	217		Drive	SCR - Selective catalytic reduction			V								
S-CLASS	217		Drive	SG-EM - Power electronics											
S-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump											
S-CLASS	217		Drive	DTR - Distronic											
S-CLASS	217		Drive	ISM - Intelligent servo module	V										
S-CLASS	217		Drive	PTCU - Common powertrain controller											
S-CLASS	217		Drive	ME/CDI/CNG - Engine control unit								V	V		
S-CLASS	217		Drive	ETC - Electronic transmission control											
S-CLASS	217		Chassis	TPM - Tire pressure monitor											
S-CLASS	217		Chassis	ABS/ESP - Electronic stability program											
S-CLASS	217		Chassis	ES - Electrical power steering											
S-CLASS	217		Chassis	Suspension											
S-CLASS	217		Chassis	EFB - Electric parking brake											
S-CLASS	217		Information	TPAD - Touchpad											
S-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio											
S-CLASS	217		Information	360' - Camera											
S-CLASS	217		Information	SOUND - Sound system											
S-CLASS	217		Information	RFK - Backup camera											
S-CLASS	217		Information	SGR - Radar sensors control unit											
S-CLASS	217		Information	PTS - Parktronic system											
S-CLASS	217		Information	NSA - Night View Assist											
S-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar											
S-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar											
S-CLASS	217		Information	NBR-RF - Right front range radar											
S-CLASS	217		Information	NBR-LF - Left front range radar											
S-CLASS	217		Information	MFK - Multifunction camera											
S-CLASS	217		Information	Head-up display											
S-CLASS	217		Information	AUDIO/COMAND											
S-CLASS	217		Information	ZAN - Audio/COMAND display											
S-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit											
S-CLASS	217		Information	KAB - Camera cover											
S-CLASS	217		Information	IC - Instrument cluster											
S-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box											
S-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection											
S-CLASS	217		Body	SCM [MRM] - Steering column module											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
S-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
S-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
S-CLASS	217		Body	AB - Airbag											
S-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
S-CLASS	217		Body	Headlamp-R - Headlamp control unit											
S-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit											V
S-CLASS	217		Body	SG-AWF - Collision prevention assist											
S-CLASS	217		Body	EZS/EIS - Electronic ignition lock											
S-CLASS	217		Body	BNS/BMS - Battery sensor											
S-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
S-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
S-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
S-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver											
S-CLASS	217		Seat/Door	HKS - Tailgate control											
S-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
S-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
S-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
S-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control											
S-CLASS	217		Seat/Door	DCM-FR - Door control module front right											
S-CLASS	217		Seat/Door	DCM-FL - Door control module front left											
S-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control											
S-CLASS	217		Air Conditioning	AAC - Automatic air conditioning											
S-CLASS	222		Drive	SCR - Selective catalytic reduction			V								
S-CLASS	222		Drive	SG-EM - Power electronics											
S-CLASS	222		Drive	FSCU/FSCU-L - Control unit Fuel pump											
S-CLASS	222		Drive	DTR - Distronic											
S-CLASS	222		Drive	ISM - Intelligent servo module	V										
S-CLASS	222		Drive	PTCU - Common powertrain controller											
S-CLASS	222		Drive	ME/CDI/CNG - Engine control unit								V	V		
S-CLASS	222		Drive	ETC - Electronic transmission control											
S-CLASS	222		Chassis	TPM - Tire pressure monitor											
S-CLASS	222		Chassis	ES - Electrical power steering											
S-CLASS	222		Chassis	ABS/ESP - Electronic stability program											
S-CLASS	222		Chassis	Suspension											
S-CLASS	222		Chassis	EFB - Electric parking brake											
S-CLASS	222		Information	TPAD - Touchpad											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
S-CLASS	222		Information	DAB/SDAR - Digital/Satellite radio											
S-CLASS	222		Information	360' - Camera											
S-CLASS	222		Information	Sound generator for exhaust system											
S-CLASS	222		Information	SOUND - Sound system											
S-CLASS	222		Information	RFK - Backup camera											
S-CLASS	222		Information	SGR - Radar sensors control unit											
S-CLASS	222		Information	PTS - Parktronic system											
S-CLASS	222		Information	NSA - Night View Assist											
S-CLASS	222		Information	NBR-LR/IRS-HLA - Left rear range radar											
S-CLASS	222		Information	NBR-RR/IRS-HRA - Right rear range radar											
S-CLASS	222		Information	NBR-RF - Right front range radar											
S-CLASS	222		Information	NBR-LF - Left front range radar											
S-CLASS	222		Information	MFK - Multifunction camera											
S-CLASS	222		Information	Head-up display											
S-CLASS	222		Information	AUDIO/COMAND											
S-CLASS	222		Information	AVE-H - Rear audio video unit											
S-CLASS	222		Information	ZAN - Audio/COMAND display											
S-CLASS	222		Information	D-FOR - Display in right rear passenger											
S-CLASS	222		Information	D-FOL - Display in left rear passenger											
S-CLASS	222		Information	COU [ZBE] - Audio/COMAND operating unit											
S-CLASS	222		Information	KAB - Camera cover											
S-CLASS	222		Information	IC - Instrument cluster											
S-CLASS	222		Information	DTA - Mbrace or TELEAID/GPS Box											
S-CLASS	222		Body	ATA - ATA [EDW]/tow-away/interior protection											
S-CLASS	222		Body	AHE - Trailer recognition											
S-CLASS	222		Body	SCM [MRM] - Steering column module											
S-CLASS	222		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
S-CLASS	222		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
S-CLASS	222		Body	AB - Airbag											
S-CLASS	222		Body	Multifunction control unit											
S-CLASS	222		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
S-CLASS	222		Body	Headlamp-R - Headlamp control unit											
S-CLASS	222		Body	Headlamp/Headlamp-L - Headlamp control unit											V
S-CLASS	222		Body	FLANFS - Fire extinguishing system and emergency fresh air system											
S-CLASS	222		Body	SG-AWF - Collision prevention assist											
S-CLASS	222		Body	EZS/EIS - Electronic ignition lock											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
S-CLASS	222		Body	BNS/BMS - Battery sensor											
S-CLASS	222		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
S-CLASS	222		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
S-CLASS	222		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
S-CLASS	222		Seat/Door	ESA Driver - Electric seat adjustment Driver											
S-CLASS	222		Seat/Door	Right rear ESE - Right electrical seat adjustment											
S-CLASS	222		Seat/Door	Left rear ESE - Left electrical seat adjustment											
S-CLASS	222		Seat/Door	HKS - Tailgate control											
S-CLASS	222		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
S-CLASS	222		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat											
S-CLASS	222		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat											
S-CLASS	222		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
S-CLASS	222		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
S-CLASS	222		Seat/Door	PSD/MSC - Sliding roof control											
S-CLASS	222		Seat/Door	DCM-RR - Door control module rear right											
S-CLASS	222		Seat/Door	DCM-RL - Door control module rear left											
S-CLASS	222		Seat/Door	DCM-FR - Door control module front right											
S-CLASS	222		Seat/Door	DCM-FL - Door control module front left											
S-CLASS	222		Air Conditioning	TSTH/STH - Stationary heater with remote control											
S-CLASS	222		Air Conditioning	AAC - Automatic air conditioning											
G-CLASS	461 - 38P Connector		Drive	EVE											
G-CLASS	461 - 38P Connector		Chassis	ABS/ESP - Electronic stability program											
G-CLASS	461 - 38P Connector		Body	AB - Airbag											
G-CLASS	461 - 38P Connector		Information	IC - Instrument cluster											
G-CLASS	461 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control											
G-CLASS	461 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit								V	V		
G-CLASS	461 - 16P Connector		Drive	ETC - Electronic transmission control											
G-CLASS	461 - 16P Connector		Drive	ESM - Electronic selector module											
G-CLASS	461 - 16P Connector		Drive	VG - Transfer case											
G-CLASS	461 - 16P Connector		Chassis	ABS/ESP - Electronic stability program											
G-CLASS	461 - 16P Connector		Chassis	TPM - Tire pressure monitor						V	V				
G-CLASS	461 - 16P Connector		Body	EZS/EIS - Electronic ignition lock											
G-CLASS	461 - 16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
G-CLASS	461 - 16P Connector		Body	CGW - Central gateway											
G-CLASS	461 - 16P Connector		Body	AB - Airbag											
G-CLASS	461 - 16P Connector		Information	IC - Instrument cluster											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
G-CLASS	461 - 16P Connector		Information	AGW - Audio gateway											
G-CLASS	461 - 16P Connector		Information	AUDIO/COMAND											
G-CLASS	461 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control											
G-CLASS	463 - 38P Connector		Drive	ME/CDI/CNG - Engine control unit											
G-CLASS	463 - 38P Connector		Drive	ETC - Electronic transmission control											
G-CLASS	463 - 38P Connector		Drive	ESM - Electronic selector module											
G-CLASS	463 - 38P Connector		Drive	CC - Cruise control											
G-CLASS	463 - 38P Connector		Chassis	ABS/ESP - Electronic stability program											
G-CLASS	463 - 38P Connector		Body	AB - Airbag											
G-CLASS	463 - 38P Connector		Information	IC - Instrument cluster				V							
G-CLASS	463 - 38P Connector		Information	AUDIO/COMAND											
G-CLASS	463 - 38P Connector		Information	APS - Auto pilot system											
G-CLASS	463 - 38P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control											
G-CLASS	463 - 16P Connector		Drive	ME/CDI/CNG - Engine control unit								V	V		
G-CLASS	463 - 16P Connector		Drive	ETC - Electronic transmission control											
G-CLASS	463 - 16P Connector		Drive	ESM - Electronic selector module											
G-CLASS	463 - 16P Connector		Drive	VG - Transfer case											
G-CLASS	463 - 16P Connector		Drive	SCR - Selective catalytic reduction			V								
G-CLASS	463 - 16P Connector		Drive	ISM - Intelligent servo module	V										
G-CLASS	463 - 16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump											
G-CLASS	463 - 16P Connector		Drive	DTR - Distronic											
G-CLASS	463 - 16P Connector		Drive	DSI - Direct select interface											
G-CLASS	463 - 16P Connector		Chassis	ABS/ESP - Electronic stability program											
G-CLASS	463 - 16P Connector		Chassis	TPM - Tire pressure monitor						V	V				
G-CLASS	463 - 16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system											
G-CLASS	463 - 16P Connector		Body	UCP - Upper control panel											
G-CLASS	463 - 16P Connector		Body	SCM [MRM] - Steering column module											
G-CLASS	463 - 16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
G-CLASS	463 - 16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
G-CLASS	463 - 16P Connector		Body	OCP - Overhead control panel					V						
G-CLASS	463 - 16P Connector		Body	Multifunction control unit											
G-CLASS	463 - 16P Connector		Body	HSW/LRH - Steering wheel heater											
G-CLASS	463 - 16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit											V
G-CLASS	463 - 16P Connector		Body	EZS/EIS - Electronic ignition lock											
G-CLASS	463 - 16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection											
G-CLASS	463 - 16P Connector		Body	AHE - Trailer recognition											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
G-CLASS	463 - 16P Connector		Body	AB - Airbag											
G-CLASS	463 - 16P Connector		Information	ZAN - Audio/COMAND display											
G-CLASS	463 - 16P Connector		Information	TV - TV tuner											
G-CLASS	463 - 16P Connector		Information	SOUND - Sound system											
G-CLASS	463 - 16P Connector		Information	PTS - Parktronic system											
G-CLASS	463 - 16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar											
G-CLASS	463 - 16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar											
G-CLASS	463 - 16P Connector		Information	NAV - Navigation module											
G-CLASS	463 - 16P Connector		Information	MIF/UCI - Media interface											
G-CLASS	463 - 16P Connector		Information	IC - Instrument cluster				V							
G-CLASS	463 - 16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box		V									
G-CLASS	463 - 16P Connector		Information	DAB/SDAR - Digital/Satellite radio											
G-CLASS	463 - 16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone											
G-CLASS	463 - 16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit											
G-CLASS	463 - 16P Connector		Information	AUDIO/COMAND											
G-CLASS	463 - 16P Connector		Information	AGW - Audio gateway											
G-CLASS	463 - 16P Connector		Seat/Door	HS - Seat heater											
G-CLASS	463 - 16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
G-CLASS	463 - 16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver											
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RR - Door control module rear right											
G-CLASS	463 - 16P Connector		Seat/Door	DCM-RL - Door control module rear left											
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FR - Door control module front right											
G-CLASS	463 - 16P Connector		Seat/Door	DCM-FL - Door control module front left											
G-CLASS	463 - 16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control											
G-CLASS	463 - 16P Connector		Air Conditioning	AAC - Automatic air conditioning											
GLA-CLASS	156		Drive	VG - Transfer case											
GLA-CLASS	156		Drive	ME/CDI/CNG - Engine control unit								V	V		
GLA-CLASS	156		Drive	FSCU/FSCU-L - Control unit Fuel pump											
GLA-CLASS	156		Drive	ETC - Electronic transmission control											
GLA-CLASS	156		Drive	DTR - Distronic											
GLA-CLASS	156		Drive	DSI - Direct select interface											
GLA-CLASS	156		Drive	PTCU - Common powertrain controller											
GLA-CLASS	156		Chassis	ABS/ESP - Electronic stability program											
GLA-CLASS	156		Chassis	ES - Electrical power steering											
GLA-CLASS	156		Chassis	EFB - Electric parking brake											
GLA-CLASS	156		Chassis	TPM - Tire pressure monitor						V	V				

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
GLA-CLASS	156		Body	SG-AWF - Collision prevention assist											
GLA-CLASS	156		Body	SCM [MRM] - Steering column module											
GLA-CLASS	156		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
GLA-CLASS	156		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
GLA-CLASS	156		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
GLA-CLASS	156		Body	Multifunction control unit											
GLA-CLASS	156		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
GLA-CLASS	156		Body	Headlamp/Headlamp-L - Headlamp control unit											V
GLA-CLASS	156		Body	EZS/EIS - Electronic ignition lock											
GLA-CLASS	156		Body	ATA - ATA [EDW]/tow-away/interior protection											
GLA-CLASS	156		Body	AHE - Trailer recognition											
GLA-CLASS	156		Body	AB - Airbag											
GLA-CLASS	156		Information	Head-up display											
GLA-CLASS	156		Information	Drive Kit Plus - Drive kit for iPhone(R)											
GLA-CLASS	156		Information	KAB - Camera cover											
GLA-CLASS	156		Information	ZAN - Audio/COMAND display											
GLA-CLASS	156		Information	TV - TV tuner											
GLA-CLASS	156		Information	SOUND - Sound system											
GLA-CLASS	156		Information	RFK - Backup camera											
GLA-CLASS	156		Information	MFK - Multifunction camera											
GLA-CLASS	156		Information	PTS - Parktronic system											
GLA-CLASS	156		Information	NBR-RR/IRS-HRA - Right rear range radar											
GLA-CLASS	156		Information	NBR-LR/IRS-HLA - Left rear range radar											
GLA-CLASS	156		Information	NAV - Navigation module											
GLA-CLASS	156		Information	MIF/UCI - Media interface											
GLA-CLASS	156		Information	IC - Instrument cluster											
GLA-CLASS	156		Information	DTA - Mbrace or TELEAID/GPS Box											
GLA-CLASS	156		Information	DAB/SDAR - Digital/Satellite radio											
GLA-CLASS	156		Information	COU [ZBE] - Audio/COMAND operating unit											
GLA-CLASS	156		Information	AUDIO/COMAND											
GLA-CLASS	156		Seat/Door	HKS - Tailgate control											
GLA-CLASS	156		Seat/Door	PSD/MSC - Sliding roof control											
GLA-CLASS	156		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
GLA-CLASS	156		Seat/Door	ESA Driver - Electric seat adjustment Driver											
GLA-CLASS	156		Seat/Door	DCM-FR - Door control module front right											
GLA-CLASS	156		Seat/Door	DCM-FL - Door control module front left											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
GLA-CLASS	156		Air Conditioning	TSTH/STH - Stationary heater with remote control											
GLA-CLASS	156		Air Conditioning	AAC - Automatic air conditioning											
GLK-CLASS	204		Drive	ME/CDI/CNG - Engine control unit								V	V		
GLK-CLASS	204		Drive	ETC - Electronic transmission control											
GLK-CLASS	204		Drive	ESM - Electronic selector module											
GLK-CLASS	204		Drive	SCR - Selective catalytic reduction			V								
GLK-CLASS	204		Drive	PTCU - Common powertrain controller											
GLK-CLASS	204		Drive	ISM - Intelligent servo module	V										
GLK-CLASS	204		Drive	FSCU-R - Control unit fuel pump											
GLK-CLASS	204		Drive	FSCU/FSCU-L - Control unit Fuel pump											
GLK-CLASS	204		Drive	DTR - Distronic											
GLK-CLASS	204		Drive	AMG DRIVE UNIT											
GLK-CLASS	204		Chassis	ABS/ESP - Electronic stability program											
GLK-CLASS	204		Chassis	Suspension											
GLK-CLASS	204		Chassis	ES - Electrical power steering											
GLK-CLASS	204		Chassis	TPM - Tire pressure monitor						V	V				
GLK-CLASS	204		Body	WSS - Weight sensing system											
GLK-CLASS	204		Body	SCM [MRM] - Steering column module											
GLK-CLASS	204		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
GLK-CLASS	204		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
GLK-CLASS	204		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
GLK-CLASS	204		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
GLK-CLASS	204		Body	OCP - Overhead control panel											
GLK-CLASS	204		Body	Multifunction control unit											
GLK-CLASS	204		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
GLK-CLASS	204		Body	Headlamp-R - Headlamp control unit											
GLK-CLASS	204		Body	Headlamp/Headlamp-L - Headlamp control unit											V
GLK-CLASS	204		Body	EZS/EIS - Electronic ignition lock											
GLK-CLASS	204		Body	CGW - Central gateway											
GLK-CLASS	204		Body	AHE - Trailer recognition											
GLK-CLASS	204		Body	AB - Airbag											
GLK-CLASS	204		Information	Head-up display											
GLK-CLASS	204		Information	AVE-H - Rear audio video unit											
GLK-CLASS	204		Information	Drive Kit Plus - Drive kit for iPhone(R)											
GLK-CLASS	204		Information	ZAN - Audio/COMAND display											
GLK-CLASS	204		Information	TV - TV tuner											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
GLK-CLASS	204		Information	Sound generator for exhaust system											
GLK-CLASS	204		Information	SOUND - Sound system											
GLK-CLASS	204		Information	SGR - Radar sensors control unit											
GLK-CLASS	204		Information	360' - Camera											
GLK-CLASS	204		Information	MFK - Multifunction camera											
GLK-CLASS	204		Information	RFK - Backup camera											
GLK-CLASS	204		Information	PTS - Parktronic system											
GLK-CLASS	204		Information	NBR-RR/IRS-HRA - Right rear range radar											
GLK-CLASS	204		Information	NBR-RF - Right front range radar											
GLK-CLASS	204		Information	NBR-LR/IRS-HLA - Left rear range radar											
GLK-CLASS	204		Information	NBR-LF - Left front range radar											
GLK-CLASS	204		Information	NAV - Navigation module											
GLK-CLASS	204		Information	MIF/UCI - Media interface											
GLK-CLASS	204		Information	ICI - InCar Internet											
GLK-CLASS	204		Information	IC - Instrument cluster											
GLK-CLASS	204		Information	DVD player											
GLK-CLASS	204		Information	DTA - Mbrace or TELEAID/GPS Box											
GLK-CLASS	204		Information	D-FOR - Display in right rear passenger											
GLK-CLASS	204		Information	D-FOL - Display in left rear passenger											
GLK-CLASS	204		Information	DAB/SDAR - Digital/Satellite radio											
GLK-CLASS	204		Information	CTEL/TEL - Cellular/Mobile telephone											
GLK-CLASS	204		Information	COU [ZBE] - Audio/COMAND operating unit											
GLK-CLASS	204		Information	AUDIO/COMAND											
GLK-CLASS	204		Information	AMG Performance Media											
GLK-CLASS	204		Seat/Door	PSD/MSC - Sliding roof control											
GLK-CLASS	204		Seat/Door	HKS - Tailgate control											
GLK-CLASS	204		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
GLK-CLASS	204		Seat/Door	ESA Driver - Electric seat adjustment Driver											
GLK-CLASS	204		Seat/Door	DCM-RR - Door control module rear right											
GLK-CLASS	204		Seat/Door	DCM-RL - Door control module rear left											
GLK-CLASS	204		Seat/Door	DCM-FR - Door control module front right											
GLK-CLASS	204		Seat/Door	DCM-FL - Door control module front left											
GLK-CLASS	204		Air Conditioning	TSTH/STH - Stationary heater with remote control											
GLK-CLASS	204		Air Conditioning	AAC - Automatic air conditioning											
GLC-CLASS	253		Drive	SCR - Selective catalytic reduction			V								
GLC-CLASS	253		Drive	SG-EM - Power electronics											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
GLC-CLASS	253		Drive	FSCU/FSCU-L - Control unit Fuel pump											
GLC-CLASS	253		Drive	DTR - Distronic											
GLC-CLASS	253		Drive	ISM - Intelligent servo module	V										
GLC-CLASS	253		Drive	PTCU - Common powertrain controller											
GLC-CLASS	253		Drive	ME/CDI/CNG - Engine control unit								V	V		
GLC-CLASS	253		Drive	ETC - Electronic transmission control											
GLC-CLASS	253		Chassis	TPM - Tire pressure monitor											
GLC-CLASS	253		Chassis	AIRMATIC PLUS											
GLC-CLASS	253		Chassis	ES - Electrical power steering											
GLC-CLASS	253		Chassis	Suspension											
GLC-CLASS	253		Chassis	ABS/ESP - Electronic stability program											
GLC-CLASS	253		Body	ATA - ATA [EDW]/tow-away/interior protection											
GLC-CLASS	253		Body	AHE - Trailer recognition											
GLC-CLASS	253		Body	SCM [MRM] - Steering column module											
GLC-CLASS	253		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
GLC-CLASS	253		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
GLC-CLASS	253		Body	AB - Airbag											
GLC-CLASS	253		Body	Multifunction control unit											
GLC-CLASS	253		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
GLC-CLASS	253		Body	Headlamp-R - Headlamp control unit											
GLC-CLASS	253		Body	Headlamp/Headlamp-L - Headlamp control unit											V
GLC-CLASS	253		Body	SG-AWF - Collision prevention assist											
GLC-CLASS	253		Body	EZS/EIS - Electronic ignition lock											
GLC-CLASS	253		Body	BNS/BMS - Battery sensor											
GLC-CLASS	253		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
GLC-CLASS	253		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
GLC-CLASS	253		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
GLC-CLASS	253		Seat/Door	ESA Driver - Electric seat adjustment Driver											
GLC-CLASS	253		Seat/Door	PSD/MSC - Sliding roof control											
GLC-CLASS	253		Seat/Door	HKS - Tailgate control											
GLC-CLASS	253		Seat/Door	DCM-RR - Door control module rear right											
GLC-CLASS	253		Seat/Door	DCM-RL - Door control module rear left											
GLC-CLASS	253		Seat/Door	DCM-FR - Door control module front right											
GLC-CLASS	253		Seat/Door	DCM-FL - Door control module front left											
GLC-CLASS	253		Information	TPAD - Touchpad											
GLC-CLASS	253		Information	DAB/SDAR - Digital/Satellite radio											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
GLC-CLASS	253		Information	360' - Camera											
GLC-CLASS	253		Information	Sound generator for exhaust system											
GLC-CLASS	253		Information	SOUND - Sound system											
GLC-CLASS	253		Information	RFK - Backup camera											
GLC-CLASS	253		Information	SGR - Radar sensors control unit											
GLC-CLASS	253		Information	PTS - Parktronic system											
GLC-CLASS	253		Information	NBR-RF - Right front range radar											
GLC-CLASS	253		Information	NBR-LF - Left front range radar											
GLC-CLASS	253		Information	MFK - Multifunction camera											
GLC-CLASS	253		Information	IC - Instrument cluster											
GLC-CLASS	253		Information	NBR-LR/IRS-HLA - Left rear range radar											
GLC-CLASS	253		Information	NBR-RR/IRS-HRA - Right rear range radar											
GLC-CLASS	253		Information	Head-up display											
GLC-CLASS	253		Information	AUDIO/COMAND											
GLC-CLASS	253		Information	SG-MSND - Engine sound											
GLC-CLASS	253		Information	ZAN - Audio/COMAND display											
GLC-CLASS	253		Information	COU [ZBE] - Audio/COMAND operating unit											
GLC-CLASS	253		Information	KAB - Camera cover											
GLC-CLASS	253		Information	DTA - Mbrace or TELEAID/GPS Box											
GLC-CLASS	253		Information	AMG Performance Media											
GLC-CLASS	253		Air Conditioning	AAC - Automatic air conditioning											
GLE-CLASS	292		Drive	SCR - Selective catalytic reduction			V								
GLE-CLASS	292		Drive	FSCU/FSCU-L - Control unit Fuel pump											
GLE-CLASS	292		Drive	ISM - Intelligent servo module	V										
GLE-CLASS	292		Drive	DTR - Distronic											
GLE-CLASS	292		Drive	ME/CDI/CNG - Engine control unit								V	V		
GLE-CLASS	292		Drive	ETC - Electronic transmission control											
GLE-CLASS	292		Chassis	TPM - Tire pressure monitor						V	V				
GLE-CLASS	292		Chassis	FWGW - Chassis gateway											
GLE-CLASS	292		Chassis	ABS/ESP - Electronic stability program											
GLE-CLASS	292		Chassis	ES - Electrical power steering											
GLE-CLASS	292		Chassis	EFB - Electric parking brake											
GLE-CLASS	292		Chassis	Suspension											
GLE-CLASS	292		Body	ATA - ATA [EDW]/tow-away/interior protection											
GLE-CLASS	292		Body	AHE - Trailer recognition											
GLE-CLASS	292		Body	SCM [MRM] - Steering column module											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
GLE-CLASS	292		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
GLE-CLASS	292		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
GLE-CLASS	292		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
GLE-CLASS	292		Body	AB - Airbag											
GLE-CLASS	292		Body	Multifunction control unit											
GLE-CLASS	292		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
GLE-CLASS	292		Body	Headlamp-R - Headlamp control unit											
GLE-CLASS	292		Body	Headlamp/Headlamp-L - Headlamp control unit											V
GLE-CLASS	292		Body	SG-AWF - Collision prevention assist											
GLE-CLASS	292		Body	EZS/EIS - Electronic ignition lock											
GLE-CLASS	292		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
GLE-CLASS	292		Information	TPAD - Touchpad											
GLE-CLASS	292		Information	DAB/SDAR - Digital/Satellite radio											
GLE-CLASS	292		Information	360' - Camera											
GLE-CLASS	292		Information	SOUND - Sound system											
GLE-CLASS	292		Information	RFK - Backup camera											
GLE-CLASS	292		Information	SGR - Radar sensors control unit											
GLE-CLASS	292		Information	PTS - Parktronic system											
GLE-CLASS	292		Information	MFK - Multifunction camera											
GLE-CLASS	292		Information	NBR-RF - Right front range radar											
GLE-CLASS	292		Information	NBR-LF - Left front range radar											
GLE-CLASS	292		Information	IC - Instrument cluster											
GLE-CLASS	292		Information	NBR-LR/IRS-HLA - Left rear range radar											
GLE-CLASS	292		Information	NBR-RR/IRS-HRA - Right rear range radar											
GLE-CLASS	292		Information	Head-up display											
GLE-CLASS	292		Information	AUDIO/COMAND											
GLE-CLASS	292		Information	AVE-H - Rear audio video unit											
GLE-CLASS	292		Information	DVD player											
GLE-CLASS	292		Information	SG-MSND - Engine sound											
GLE-CLASS	292		Information	ZAN - Audio/COMAND display											
GLE-CLASS	292		Information	D-FOR - Display in right rear passenger											
GLE-CLASS	292		Information	D-FOL - Display in left rear passenger											
GLE-CLASS	292		Information	COU [ZBE] - Audio/COMAND operating unit											
GLE-CLASS	292		Information	DTA - Mbrace or TELEAID/GPS Box											
GLE-CLASS	292		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
GLE-CLASS	292		Seat/Door	ESA Driver - Electric seat adjustment Driver											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
GLE-CLASS	292		Seat/Door	PSD/MSC - Sliding roof control											
GLE-CLASS	292		Seat/Door	HKS - Tailgate control											
GLE-CLASS	292		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
GLE-CLASS	292		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
GLE-CLASS	292		Seat/Door	DCM-RR - Door control module rear right											
GLE-CLASS	292		Seat/Door	DCM-RL - Door control module rear left											
GLE-CLASS	292		Seat/Door	DCM-FR - Door control module front right											
GLE-CLASS	292		Seat/Door	DCM-FL - Door control module front left											
GLE-CLASS	292		Air Conditioning	TSTH/STH - Stationary heater with remote control											
GLE-CLASS	292		Air Conditioning	HBF - Rear control panel											
GLE-CLASS	292		Air Conditioning	AAC - Automatic air conditioning											
GL-CLASS	164		Drive	ME/CDI/CNG - Engine control unit								V	V		
GL-CLASS	164		Drive	ETC - Electronic transmission control											
GL-CLASS	164		Drive	VG - Transfer case											
GL-CLASS	164		Drive	SG-EM-B - Electric motor control unit B											
GL-CLASS	164		Drive	SG-EM-A - Electric motor control unit A											
GL-CLASS	164		Drive	SCR - Selective catalytic reduction			V								
GL-CLASS	164		Drive	ISM - Intelligent servo module	V										
GL-CLASS	164		Drive	HSG - Hybrid control unit											
GL-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump											
GL-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter											
GL-CLASS	164		Drive	DTR - Distronic											
GL-CLASS	164		Chassis	ABS/ESP - Electronic stability program											
GL-CLASS	164		Chassis	Suspension											
GL-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle											
GL-CLASS	164		Chassis	ES - Electrical power steering											
GL-CLASS	164		Chassis	TPM - Tire pressure monitor											
GL-CLASS	164		Body	WSS - Weight sensing system										V	
GL-CLASS	164		Body	UCP - Upper control panel											
GL-CLASS	164		Body	System diagnosis											
GL-CLASS	164		Body	SCM [MRM] - Steering column module											
GL-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
GL-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
GL-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
GL-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
GL-CLASS	164		Body	OCP - Overhead control panel					V						

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
GL-CLASS	164		Body	LCP/HBF - Lower/Rear control panel											
GL-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
GL-CLASS	164		Body	Headlamp-R - Headlamp control unit											
GL-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit											V
GL-CLASS	164		Body	EZS/EIS - Electronic ignition lock											
GL-CLASS	164		Body	CGW - Central gateway											
GL-CLASS	164		Body	AB - Airbag											
GL-CLASS	164		Information	TV - TV tuner											
GL-CLASS	164		Information	SOUND - Sound system											
GL-CLASS	164		Information	RFK - Backup camera											
GL-CLASS	164		Information	PTS - Parktronic system											
GL-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar											
GL-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar											
GL-CLASS	164		Information	NAV - Navigation module											
GL-CLASS	164		Information	MIF/UCI - Media interface											
GL-CLASS	164		Information	IC - Instrument cluster				V							
GL-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box											
GL-CLASS	164		Information	D-FOR - Display in right rear passenger											
GL-CLASS	164		Information	D-FOL - Display in left rear passenger											
GL-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio											
GL-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone											
GL-CLASS	164		Information	CM - Compass module											
GL-CLASS	164		Information	AVE-H - Rear audio video unit											
GL-CLASS	164		Information	AUDIO/COMAND											
GL-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System											
GL-CLASS	164		Information	ASSYST Active Service System											
GL-CLASS	164		Information	AGW - Audio gateway											
GL-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module											
GL-CLASS	164		Seat/Door	HS - Seat heater											
GL-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
GL-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver											
GL-CLASS	164		Seat/Door	ERA - Electric fold down backrest system											
GL-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
GL-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
GL-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
GL-CLASS	164		Seat/Door	DCM-FR - Door control module front right											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
GL-CLASS	164		Seat/Door	DCM-FL - Door control module front left											
GL-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control											
GL-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor											
GL-CLASS	164		Air Conditioning	AAC - Automatic air conditioning											
GL-CLASS	166		Drive	SG-EM - Power electronics											
GL-CLASS	166		Drive	PTCU - Common powertrain controller											
GL-CLASS	166		Drive	ME/CDI/CNG - Engine control unit								V	V		
GL-CLASS	166		Drive	ETC - Electronic transmission control											
GL-CLASS	166		Drive	VG - Transfer case											
GL-CLASS	166		Drive	SCR - Selective catalytic reduction			V								
GL-CLASS	166		Drive	ISM - Intelligent servo module	V										
GL-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump											
GL-CLASS	166		Drive	DTR - Distronic											
GL-CLASS	166		Chassis	ABS/ESP - Electronic stability program											
GL-CLASS	166		Chassis	Suspension											
GL-CLASS	166		Chassis	ES - Electrical power steering											
GL-CLASS	166		Chassis	EFB - Electric parking brake											
GL-CLASS	166		Chassis	FWGW - Chassis gateway											
GL-CLASS	166		Chassis	TPM - Tire pressure monitor						V	V				
GL-CLASS	166		Body	SG-AWF - Collision prevention assist											
GL-CLASS	166		Body	SCM [MRM] - Steering column module											
GL-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
GL-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
GL-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
GL-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
GL-CLASS	166		Body	Multifunction control unit											
GL-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
GL-CLASS	166		Body	Headlamp-R - Headlamp control unit											
GL-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit											V
GL-CLASS	166		Body	EZS/EIS - Electronic ignition lock											
GL-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection											
GL-CLASS	166		Body	AHE - Trailer recognition											
GL-CLASS	166		Body	AB - Airbag											
GL-CLASS	166		Information	Sound generator for exhaust system											
GL-CLASS	166		Information	Head-up display											
GL-CLASS	166		Information	AVE-H - Rear audio video unit											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
GL-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)											
GL-CLASS	166		Information	ZAN - Audio/COMAND display											
GL-CLASS	166		Information	TV - TV tuner											
GL-CLASS	166		Information	SOUND - Sound system											
GL-CLASS	166		Information	SGR - Radar sensors control unit											
GL-CLASS	166		Information	360' - Camera											
GL-CLASS	166		Information	RFK - Backup camera											
GL-CLASS	166		Information	MFK - Multifunction camera											
GL-CLASS	166		Information	PTS - Parktronic system											
GL-CLASS	166		Information	NSA - Night View Assist											
GL-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar											
GL-CLASS	166		Information	NBR-RF - Right front range radar											
GL-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar											
GL-CLASS	166		Information	NBR-LF - Left front range radar											
GL-CLASS	166		Information	NAV - Navigation module											
GL-CLASS	166		Information	MIF/UCI - Media interface											
GL-CLASS	166		Information	IC - Instrument cluster											
GL-CLASS	166		Information	DVD player											
GL-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box											
GL-CLASS	166		Information	D-FOR - Display in right rear passenger											
GL-CLASS	166		Information	D-FOL - Display in left rear passenger											
GL-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio											
GL-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit											
GL-CLASS	166		Information	AUDIO/COMAND											
GL-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control											
GL-CLASS	166		Seat/Door	HKS - Tailgate control											
GL-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
GL-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver											
GL-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
GL-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
GL-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
GL-CLASS	166		Seat/Door	DCM-RR - Door control module rear right											
GL-CLASS	166		Seat/Door	DCM-RL - Door control module rear left											
GL-CLASS	166		Seat/Door	DCM-FR - Door control module front right											
GL-CLASS	166		Seat/Door	DCM-FL - Door control module front left											
GL-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
GL-CLASS	166		Air Conditioning	HBF - Rear control panel											
GL-CLASS	166		Air Conditioning	AAC - Automatic air conditioning											
M-CLASS	163		Drive	ME/CDI/CNG - Engine control unit											
M-CLASS	163		Drive	ETC - Electronic transmission control											
M-CLASS	163		Drive	ESM - Electronic selector module											
M-CLASS	163		Drive	VG - Transfer case											
M-CLASS	163		Chassis	ABS/ESP - Electronic stability program											
M-CLASS	163		Chassis	VP - Vacuum pump brake booster											
M-CLASS	163		Chassis	BAS - Brake assist											
M-CLASS	163		Body	Headlamp/Headlamp-L - Headlamp control unit											
M-CLASS	163		Body	AB - Airbag											
M-CLASS	163		Body	AAM - All activity module											
M-CLASS	163		Information	PTS - Parktronic system											
M-CLASS	163		Information	IC - Instrument cluster				V							
M-CLASS	163		Information	DTA - Mbrace or TELEAID/GPS Box		V									
M-CLASS	163		Information	AUDIO/COMAND											
M-CLASS	163		Air Conditioning	AAC - Automatic air conditioning											
M-CLASS	163		Air Conditioning	TSTH/STH - Stationary heater with remote control											
M-CLASS	164		Drive	ME/CDI/CNG - Engine control unit								V	V		
M-CLASS	164		Drive	ETC - Electronic transmission control											
M-CLASS	164		Drive	VG - Transfer case											
M-CLASS	164		Drive	SG-EM-B - Electric motor control unit B											
M-CLASS	164		Drive	SG-EM-A - Electric motor control unit A											
M-CLASS	164		Drive	SCR - Selective catalytic reduction			V								
M-CLASS	164		Drive	ISM - Intelligent servo module	V										
M-CLASS	164		Drive	HSG - Hybrid control unit											
M-CLASS	164		Drive	FSCU/FSCU-L - Control unit Fuel pump											
M-CLASS	164		Drive	EMPI - Electronic Motor Pump Inverter											
M-CLASS	164		Drive	DTR - Distronic											
M-CLASS	164		Chassis	ABS/ESP - Electronic stability program											
M-CLASS	164		Chassis	Suspension											
M-CLASS	164		Chassis	HAQ - Interwheel differential lock at rear axle											
M-CLASS	164		Chassis	ES - Electrical power steering											
M-CLASS	164		Chassis	TPM - Tire pressure monitor											
M-CLASS	164		Body	WSS - Weight sensing system										V	
M-CLASS	164		Body	UCP - Upper control panel											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
M-CLASS	164		Body	System diagnosis											
M-CLASS	164		Body	SCM [MRM] - Steering column module											
M-CLASS	164		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
M-CLASS	164		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
M-CLASS	164		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
M-CLASS	164		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
M-CLASS	164		Body	OCP - Overhead control panel					V						
M-CLASS	164		Body	LCP/HBF - Lower/Rear control panel											
M-CLASS	164		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
M-CLASS	164		Body	Headlamp-R - Headlamp control unit											
M-CLASS	164		Body	Headlamp/Headlamp-L - Headlamp control unit											V
M-CLASS	164		Body	EZS/EIS - Electronic ignition lock											
M-CLASS	164		Body	CGW - Central gateway											
M-CLASS	164		Body	AB - Airbag											
M-CLASS	164		Information	TV - TV tuner											
M-CLASS	164		Information	SOUND - Sound system											
M-CLASS	164		Information	RFK - Backup camera											
M-CLASS	164		Information	PTS - Parktronic system											
M-CLASS	164		Information	NBR-RR/IRS-HRA - Right rear range radar											
M-CLASS	164		Information	NBR-LR/IRS-HLA - Left rear range radar											
M-CLASS	164		Information	NAV - Navigation module											
M-CLASS	164		Information	MIF/UCI - Media interface											
M-CLASS	164		Information	IC - Instrument cluster				V							
M-CLASS	164		Information	DTA - Mbrace or TELEAID/GPS Box											
M-CLASS	164		Information	D-FOR - Display in right rear passenger											
M-CLASS	164		Information	D-FOL - Display in left rear passenger											
M-CLASS	164		Information	DAB/SDAR - Digital/Satellite radio											
M-CLASS	164		Information	CTEL/TEL - Cellular/Mobile telephone											
M-CLASS	164		Information	CM - Compass module											
M-CLASS	164		Information	AVE-H - Rear audio video unit											
M-CLASS	164		Information	AUDIO/COMAND											
M-CLASS	164		Information	ASSYST PLUS - PLUS Active Service System											
M-CLASS	164		Information	ASSYST Active Service System											
M-CLASS	164		Information	AGW - Audio gateway											
M-CLASS	164		Seat/Door	REDC/RWT - Rear end door control module											
M-CLASS	164		Seat/Door	HS - Seat heater											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
M-CLASS	164		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
M-CLASS	164		Seat/Door	ESA Driver - Electric seat adjustment Driver											
M-CLASS	164		Seat/Door	ERA - Electric fold down backrest system											
M-CLASS	164		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
M-CLASS	164		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
M-CLASS	164		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
M-CLASS	164		Seat/Door	DCM-FR - Door control module front right											
M-CLASS	164		Seat/Door	DCM-FL - Door control module front left											
M-CLASS	164		Air Conditioning	TSTH/STH - Stationary heater with remote control											
M-CLASS	164		Air Conditioning	EKMK - Electric refrigerant compressor											
M-CLASS	164		Air Conditioning	AAC - Automatic air conditioning											
M-CLASS	166		Drive	SG-EM - Power electronics											
M-CLASS	166		Drive	ME/CDI/CNG - Engine control unit								V	V		
M-CLASS	166		Drive	ETC - Electronic transmission control											
M-CLASS	166		Drive	VG - Transfer case											
M-CLASS	166		Drive	SCR - Selective catalytic reduction			V								
M-CLASS	166		Drive	PTCU - Common powertrain controller											
M-CLASS	166		Drive	ISM - Intelligent servo module	V										
M-CLASS	166		Drive	FSCU/FSCU-L - Control unit Fuel pump											
M-CLASS	166		Drive	DTR - Distronic											
M-CLASS	166		Chassis	ABS/ESP - Electronic stability program											
M-CLASS	166		Chassis	Suspension											
M-CLASS	166		Chassis	ES - Electrical power steering											
M-CLASS	166		Chassis	EFB - Electric parking brake											
M-CLASS	166		Chassis	FWGW - Chassis gateway											
M-CLASS	166		Chassis	TPM - Tire pressure monitor						V	V				
M-CLASS	166		Body	SG-AWF - Collision prevention assist											
M-CLASS	166		Body	SCM [MRM] - Steering column module											
M-CLASS	166		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
M-CLASS	166		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
M-CLASS	166		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
M-CLASS	166		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
M-CLASS	166		Body	Multifunction control unit											
M-CLASS	166		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
M-CLASS	166		Body	Headlamp-R - Headlamp control unit											
M-CLASS	166		Body	Headlamp/Headlamp-L - Headlamp control unit											V

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
M-CLASS	166		Body	EZS/EIS - Electronic ignition lock											
M-CLASS	166		Body	ATA - ATA [EDW]/tow-away/interior protection											
M-CLASS	166		Body	AHE - Trailer recognition											
M-CLASS	166		Body	AB - Airbag											
M-CLASS	166		Information	Sound generator for exhaust system											
M-CLASS	166		Information	Head-up display											
M-CLASS	166		Information	AVE-H - Rear audio video unit											
M-CLASS	166		Information	Drive Kit Plus - Drive kit for iPhone(R)											
M-CLASS	166		Information	ZAN - Audio/COMAND display											
M-CLASS	166		Information	TV - TV tuner											
M-CLASS	166		Information	SOUND - Sound system											
M-CLASS	166		Information	SGR - Radar sensors control unit											
M-CLASS	166		Information	360' - Camera											
M-CLASS	166		Information	RFK - Backup camera											
M-CLASS	166		Information	MFK - Multifunction camera											
M-CLASS	166		Information	PTS - Parktronic system											
M-CLASS	166		Information	NSA - Night View Assist											
M-CLASS	166		Information	NBR-RR/IRS-HRA - Right rear range radar											
M-CLASS	166		Information	NBR-RF - Right front range radar											
M-CLASS	166		Information	NBR-LR/IRS-HLA - Left rear range radar											
M-CLASS	166		Information	NBR-LF - Left front range radar											
M-CLASS	166		Information	NAV - Navigation module											
M-CLASS	166		Information	MIF/UCI - Media interface											
M-CLASS	166		Information	IC - Instrument cluster											
M-CLASS	166		Information	DVD player											
M-CLASS	166		Information	DTA - Mbrace or TELEAID/GPS Box											
M-CLASS	166		Information	D-FOR - Display in right rear passenger											
M-CLASS	166		Information	D-FOL - Display in left rear passenger											
M-CLASS	166		Information	DAB/SDAR - Digital/Satellite radio											
M-CLASS	166		Information	COU [ZBE] - Audio/COMAND operating unit											
M-CLASS	166		Information	AUDIO/COMAND											
M-CLASS	166		Seat/Door	PSD/MSC - Sliding roof control											
M-CLASS	166		Seat/Door	HKS - Tailgate control											
M-CLASS	166		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
M-CLASS	166		Seat/Door	ESA Driver - Electric seat adjustment Driver											
M-CLASS	166		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
M-CLASS	166		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
M-CLASS	166		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
M-CLASS	166		Seat/Door	DCM-RR - Door control module rear right											
M-CLASS	166		Seat/Door	DCM-RL - Door control module rear left											
M-CLASS	166		Seat/Door	DCM-FR - Door control module front right											
M-CLASS	166		Seat/Door	DCM-FL - Door control module front left											
M-CLASS	166		Air Conditioning	TSTH/STH - Stationary heater with remote control											
M-CLASS	166		Air Conditioning	HBF - Rear control panel											
M-CLASS	166		Air Conditioning	AAC - Automatic air conditioning											
R-CLASS	251		Drive	ME/CDI/CNG - Engine control unit								V	V		
R-CLASS	251		Drive	ETC - Electronic transmission control											
R-CLASS	251		Drive	SCR - Selective catalytic reduction			V								
R-CLASS	251		Drive	ISM - Intelligent servo module	V										
R-CLASS	251		Drive	FSCU/FSCU-L - Control unit Fuel pump											
R-CLASS	251		Drive	DTR - Distronic											
R-CLASS	251		Chassis	ABS/ESP - Electronic stability program											
R-CLASS	251		Chassis	Suspension											
R-CLASS	251		Chassis	ES - Electrical power steering											
R-CLASS	251		Chassis	TPM - Tire pressure monitor											
R-CLASS	251		Body	WSS - Weight sensing system										V	
R-CLASS	251		Body	UCP - Upper control panel											
R-CLASS	251		Body	System diagnosis											
R-CLASS	251		Body	SCM [MRM] - Steering column module											
R-CLASS	251		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
R-CLASS	251		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
R-CLASS	251		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
R-CLASS	251		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
R-CLASS	251		Body	OCP - Overhead control panel					V						
R-CLASS	251		Body	LCP/HBF - Lower/Rear control panel											
R-CLASS	251		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
R-CLASS	251		Body	Headlamp-R - Headlamp control unit											
R-CLASS	251		Body	Headlamp/Headlamp-L - Headlamp control unit											V
R-CLASS	251		Body	EZS/EIS - Electronic ignition lock											
R-CLASS	251		Body	CGW - Central gateway											
R-CLASS	251		Body	AB - Airbag											
R-CLASS	251		Information	TV - TV tuner											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
R-CLASS	251		Information	SOUND - Sound system											
R-CLASS	251		Information	RFK - Backup camera											
R-CLASS	251		Information	PTS - Parktronic system											
R-CLASS	251		Information	NBR-RR/IRS-HRA - Right rear range radar											
R-CLASS	251		Information	NBR-LR/IRS-HLA - Left rear range radar											
R-CLASS	251		Information	NAV - Navigation module											
R-CLASS	251		Information	MIF/UCI - Media interface											
R-CLASS	251		Information	IC - Instrument cluster				V							
R-CLASS	251		Information	DTA - Mbrace or TELEAID/GPS Box											
R-CLASS	251		Information	D-FOR - Display in right rear passenger											
R-CLASS	251		Information	D-FOL - Display in left rear passenger											
R-CLASS	251		Information	DAB/SDAR - Digital/Satellite radio											
R-CLASS	251		Information	CTEL/TEL - Cellular/Mobile telephone											
R-CLASS	251		Information	CM - Compass module											
R-CLASS	251		Information	AVE-H - Rear audio video unit											
R-CLASS	251		Information	AUDIO/COMAND											
R-CLASS	251		Information	ASSYST PLUS - PLUS Active Service System											
R-CLASS	251		Information	ASSYST Active Service System											
R-CLASS	251		Information	AGW - Audio gateway											
R-CLASS	251		Seat/Door	REDC/RWT - Rear end door control module											
R-CLASS	251		Seat/Door	HS - Seat heater											
R-CLASS	251		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
R-CLASS	251		Seat/Door	ESA Driver - Electric seat adjustment Driver											
R-CLASS	251		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
R-CLASS	251		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
R-CLASS	251		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
R-CLASS	251		Seat/Door	DCM-FR - Door control module front right											
R-CLASS	251		Seat/Door	DCM-FL - Door control module front left											
R-CLASS	251		Air Conditioning	TSTH/STH - Stationary heater with remote control											
R-CLASS	251		Air Conditioning	AAC - Automatic air conditioning											
CLA-CLASS	117		Drive	VG - Transfer case											
CLA-CLASS	117		Drive	ME/CDI/CNG - Engine control unit								V	V		
CLA-CLASS	117		Drive	ETC - Electronic transmission control											
CLA-CLASS	117		Drive	FSCU/FSCU-L - Control unit Fuel pump											
CLA-CLASS	117		Drive	DTR - Distronic											
CLA-CLASS	117		Drive	DSI - Direct select interface											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
CLA-CLASS	117		Drive	PTCU - Common powertrain controller											
CLA-CLASS	117		Chassis	ABS/ESP - Electronic stability program											
CLA-CLASS	117		Chassis	ES - Electrical power steering											
CLA-CLASS	117		Chassis	EFB - Electric parking brake											
CLA-CLASS	117		Chassis	TPM - Tire pressure monitor						V	V				
CLA-CLASS	117		Body	SG-AWF - Collision prevention assist											
CLA-CLASS	117		Body	SCM [MRM] - Steering column module											
CLA-CLASS	117		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
CLA-CLASS	117		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
CLA-CLASS	117		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
CLA-CLASS	117		Body	Multifunction control unit											
CLA-CLASS	117		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
CLA-CLASS	117		Body	Headlamp/Headlamp-L - Headlamp control unit											V
CLA-CLASS	117		Body	EZS/EIS - Electronic ignition lock											
CLA-CLASS	117		Body	ATA - ATA [EDW]/tow-away/interior protection											
CLA-CLASS	117		Body	AHE - Trailer recognition											
CLA-CLASS	117		Body	AB - Airbag											
CLA-CLASS	117		Information	Head-up display											
CLA-CLASS	117		Information	Drive Kit Plus - Drive kit for iPhone(R)											
CLA-CLASS	117		Information	KAB - Camera cover											
CLA-CLASS	117		Information	ZAN - Audio/COMAND display											
CLA-CLASS	117		Information	TV - TV tuner											
CLA-CLASS	117		Information	SOUND - Sound system											
CLA-CLASS	117		Information	RFK - Backup camera											
CLA-CLASS	117		Information	MFK - Multifunction camera											
CLA-CLASS	117		Information	PTS - Parktronic system											
CLA-CLASS	117		Information	NBR-RR/IRS-HRA - Right rear range radar											
CLA-CLASS	117		Information	NBR-LR/IRS-HLA - Left rear range radar											
CLA-CLASS	117		Information	NAV - Navigation module											
CLA-CLASS	117		Information	MIF/UCI - Media interface											
CLA-CLASS	117		Information	IC - Instrument cluster											
CLA-CLASS	117		Information	DTA - Mbrace or TELEAID/GPS Box											
CLA-CLASS	117		Information	DAB/SDAR - Digital/Satellite radio											
CLA-CLASS	117		Information	COU [ZBE] - Audio/COMAND operating unit											
CLA-CLASS	117		Information	AUDIO/COMAND											
CLA-CLASS	117		Seat/Door	HKS - Tailgate control											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
CLA-CLASS	117		Seat/Door	PSD/MSC - Sliding roof control											
CLA-CLASS	117		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
CLA-CLASS	117		Seat/Door	ESA Driver - Electric seat adjustment Driver											
CLA-CLASS	117		Seat/Door	DCM-FR - Door control module front right											
CLA-CLASS	117		Seat/Door	DCM-FL - Door control module front left											
CLA-CLASS	117		Air Conditioning	TSTH/STH - Stationary heater with remote control											
CLA-CLASS	117		Air Conditioning	AAC - Automatic air conditioning											
CLK-CLASS	208		Drive	ME/CDI/CNG - Engine control unit											
CLK-CLASS	208		Drive	ETC - Electronic transmission control											
CLK-CLASS	208		Drive	ESM - Electronic selector module											
CLK-CLASS	208		Chassis	PSE - Pneumatic system equipment											
CLK-CLASS	208		Chassis	ABS/ESP - Electronic stability program											
CLK-CLASS	208		Chassis	VP - Vacuum pump brake booster											
CLK-CLASS	208		Chassis	BAS - Brake assist											
CLK-CLASS	208		Body	LCP/HBF - Lower/Rear control panel											
CLK-CLASS	208		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
CLK-CLASS	208		Body	EZS/EIS - Electronic ignition lock											
CLK-CLASS	208		Body	OCP - Overhead control panel											
CLK-CLASS	208		Body	AB - Airbag											
CLK-CLASS	208		Information	TV - TV tuner											
CLK-CLASS	208		Information	PTS - Parktronic system											
CLK-CLASS	208		Information	NAV - Navigation module											
CLK-CLASS	208		Information	IC - Instrument cluster				V							
CLK-CLASS	208		Information	DTA - Mbrace or TELEAID/GPS Box		V									
CLK-CLASS	208		Information	AUDIO/COMAND											
CLK-CLASS	208		Information	APS - Auto pilot system											
CLK-CLASS	208		Air Conditioning	TSTH/STH - Stationary heater with remote control											
CLK-CLASS	208		Air Conditioning	AAC - Automatic air conditioning											
CLK-CLASS	208		Seat/Door	DCM-FR - Door control module front right											
CLK-CLASS	208		Seat/Door	DCM-FL - Door control module front left											
CLK-CLASS	208		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
CLK-CLASS	208		Seat/Door	ESA Driver - Electric seat adjustment Driver											
CLK-CLASS	209		Drive	ME/CDI/CNG - Engine control unit											
CLK-CLASS	209		Drive	ETC - Electronic transmission control											
CLK-CLASS	209		Drive	ESM - Electronic selector module											
CLK-CLASS	209		Drive	DTR - Distronic											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
CLK-CLASS	209		Chassis	ABS/ESP - Electronic stability program											
CLK-CLASS	209		Chassis	TPM - Tire pressure monitor											
CLK-CLASS	209		Body	WSS - Weight sensing system										V	
CLK-CLASS	209		Body	UCP - Upper control panel											
CLK-CLASS	209		Body	SCM [MRM] - Steering column module											
CLK-CLASS	209		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
CLK-CLASS	209		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
CLK-CLASS	209		Body	RCM - Rear control module											
CLK-CLASS	209		Body	OCP - Overhead control panel					V						
CLK-CLASS	209		Body	Multifunction control unit											
CLK-CLASS	209		Body	LCP/HBF - Lower/Rear control panel											
CLK-CLASS	209		Body	Headlamp-R - Headlamp control unit											
CLK-CLASS	209		Body	Headlamp/Headlamp-L - Headlamp control unit											V
CLK-CLASS	209		Body	EZS/EIS - Electronic ignition lock											
CLK-CLASS	209		Body	BNS/BMS - Battery sensor											
CLK-CLASS	209		Body	AHE - Trailer recognition											
CLK-CLASS	209		Body	AB - Airbag											
CLK-CLASS	209		Information	TV - TV tuner											
CLK-CLASS	209		Information	PTS - Parktronic system											
CLK-CLASS	209		Information	NAV - Navigation module											
CLK-CLASS	209		Information	IC - Instrument cluster				V							
CLK-CLASS	209		Information	DTA - Mbrace or TELEAID/GPS Box		V									
CLK-CLASS	209		Information	AUDIO/COMAND											
CLK-CLASS	209		Information	AGW - Audio gateway											
CLK-CLASS	209		Seat/Door	RVC/VDS - Convertible roof control											
CLK-CLASS	209		Seat/Door	REDC/RWT - Rear end door control module											
CLK-CLASS	209		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
CLK-CLASS	209		Seat/Door	ESA Driver - Electric seat adjustment Driver											
CLK-CLASS	209		Seat/Door	DCM-FR - Door control module front right											
CLK-CLASS	209		Seat/Door	DCM-FL - Door control module front left											
CLK-CLASS	209		Air Conditioning	TSTH/STH - Stationary heater with remote control											
CLK-CLASS	209		Air Conditioning	AAC - Automatic air conditioning											
CLS-CLASS	219		Drive	ME/CDI/CNG - Engine control unit											
CLS-CLASS	219		Drive	ETC - Electronic transmission control											
CLS-CLASS	219		Drive	ESM - Electronic selector module											
CLS-CLASS	219		Drive	FSCU/FSCU-L - Control unit Fuel pump											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
CLS-CLASS	219		Drive	DTR - Distronic											
CLS-CLASS	219		Chassis	ABS/ESP - Electronic stability program											
CLS-CLASS	219		Chassis	Suspension											
CLS-CLASS	219		Chassis	SBC - Sensotronic Brake Control											
CLS-CLASS	219		Chassis	TPM - Tire pressure monitor											
CLS-CLASS	219		Body	WSS - Weight sensing system										V	
CLS-CLASS	219		Body	UCP - Upper control panel											
CLS-CLASS	219		Body	System diagnosis											
CLS-CLASS	219		Body	SCM [MRM] - Steering column module											
CLS-CLASS	219		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
CLS-CLASS	219		Body	SAM-P- Passenger-side signal acquisition and actuation module											
CLS-CLASS	219		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
CLS-CLASS	219		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
CLS-CLASS	219		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
CLS-CLASS	219		Body	OCP - Overhead control panel					V						
CLS-CLASS	219		Body	LCP/HBF - Lower/Rear control panel											
CLS-CLASS	219		Body	LAE [LAA] - Loading floor automatically extendable											
CLS-CLASS	219		Body	Headlamp/Headlamp-L - Headlamp control unit											
CLS-CLASS	219		Body	EZS/EIS - Electronic ignition lock											
CLS-CLASS	219		Body	CGW - Central gateway											
CLS-CLASS	219		Body	BNS/BMS - Battery sensor											
CLS-CLASS	219		Body	AB - Airbag											
CLS-CLASS	219		Information	TV - TV tuner											
CLS-CLASS	219		Information	SOUND - Sound system											
CLS-CLASS	219		Information	PTS - Parktronic system											
CLS-CLASS	219		Information	MIF/UCI - Media interface											
CLS-CLASS	219		Information	IC - Instrument cluster				V							
CLS-CLASS	219		Information	DTA - Mbrace or TELEAID/GPS Box											
CLS-CLASS	219		Information	DAB/SDAR - Digital/Satellite radio											
CLS-CLASS	219		Information	CTEL/TEL - Cellular/Mobile telephone											
CLS-CLASS	219		Information	AUDIO/COMAND											
CLS-CLASS	219		Information	ASSYST PLUS - PLUS Active Service System											
CLS-CLASS	219		Information	ASSYST Active Service System											
CLS-CLASS	219		Information	AGW - Audio gateway											
CLS-CLASS	219		Seat/Door	REDC/RWT - Rear end door control module											
CLS-CLASS	219		Seat/Door	HS - Seat heater											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
CLS-CLASS	219		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
CLS-CLASS	219		Seat/Door	ESA Driver - Electric seat adjustment Driver											
CLS-CLASS	219		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
CLS-CLASS	219		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
CLS-CLASS	219		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
CLS-CLASS	219		Seat/Door	DCM-RR - Door control module rear right											
CLS-CLASS	219		Seat/Door	DCM-RL - Door control module rear left											
CLS-CLASS	219		Seat/Door	DCM-FR - Door control module front right											
CLS-CLASS	219		Seat/Door	DCM-FL - Door control module front left											
CLS-CLASS	219		Air Conditioning	TSTH/STH - Stationary heater with remote control											
CLS-CLASS	219		Air Conditioning	AAC - Automatic air conditioning											
CLS-CLASS	218		Drive	ME/CDI/CNG - Engine control unit								V	V		
CLS-CLASS	218		Drive	ETC - Electronic transmission control											
CLS-CLASS	218		Drive	ESM - Electronic selector module											
CLS-CLASS	218		Drive	SCR - Selective catalytic reduction			V								
CLS-CLASS	218		Drive	ISM - Intelligent servo module	V										
CLS-CLASS	218		Drive	FSCU/FSCU-L - Control unit Fuel pump											
CLS-CLASS	218		Drive	DTR - Distronic											
CLS-CLASS	218		Drive	DSI - Direct select interface											
CLS-CLASS	218		Drive	AMG DRIVE UNIT											
CLS-CLASS	218		Chassis	ABS/ESP - Electronic stability program											
CLS-CLASS	218		Chassis	Suspension											
CLS-CLASS	218		Chassis	ES - Electrical power steering											
CLS-CLASS	218		Chassis	FWGW - Chassis gateway											
CLS-CLASS	218		Chassis	TPM - Tire pressure monitor						V	V				
CLS-CLASS	218		Body	SG-LML-VR - LED matrix of right front lamp unit											
CLS-CLASS	218		Body	SG-LML-VL - LED matrix of left front lamp unit											
CLS-CLASS	218		Body	WSS - Weight sensing system											
CLS-CLASS	218		Body	SG-AWF - Collision prevention assist											
CLS-CLASS	218		Body	SCM [MRM] - Steering column module											
CLS-CLASS	218		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
CLS-CLASS	218		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
CLS-CLASS	218		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
CLS-CLASS	218		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
CLS-CLASS	218		Body	OCP - Overhead control panel											
CLS-CLASS	218		Body	Multifunction control unit											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
CLS-CLASS	218		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
CLS-CLASS	218		Body	HSW/LRH - Steering wheel heater											
CLS-CLASS	218		Body	HS/AIRSCARF - Seat heater/Air scarf system											
CLS-CLASS	218		Body	Headlamp-R - Headlamp control unit											
CLS-CLASS	218		Body	Headlamp/Headlamp-L - Headlamp control unit											V
CLS-CLASS	218		Body	EZS/EIS - Electronic ignition lock											
CLS-CLASS	218		Body	CGW - Central gateway											
CLS-CLASS	218		Body	AHE - Trailer recognition											
CLS-CLASS	218		Body	AB - Airbag											
CLS-CLASS	218		Information	360' - Camera											
CLS-CLASS	218		Information	AVE-H - Rear audio video unit											
CLS-CLASS	218		Information	Drive Kit Plus - Drive kit for iPhone(R)											
CLS-CLASS	218		Information	ZAN - Audio/COMAND display											
CLS-CLASS	218		Information	TV - TV tuner											
CLS-CLASS	218		Information	SOUND - Sound system											
CLS-CLASS	218		Information	SGR - Radar sensors control unit											
CLS-CLASS	218		Information	MFK - Multifunction camera											
CLS-CLASS	218		Information	RFK - Backup camera											
CLS-CLASS	218		Information	PTS - Parktronic system											
CLS-CLASS	218		Information	NSA - Night View Assist											
CLS-CLASS	218		Information	NBR-RR/IRS-HRA - Right rear range radar											
CLS-CLASS	218		Information	NBR-RF - Right front range radar											
CLS-CLASS	218		Information	NBR-LR/IRS-HLA - Left rear range radar											
CLS-CLASS	218		Information	NBR-LF - Left front range radar											
CLS-CLASS	218		Information	NAV - Navigation module											
CLS-CLASS	218		Information	MIF/UCI - Media interface											
CLS-CLASS	218		Information	ICI - InCar Internet											
CLS-CLASS	218		Information	IC - Instrument cluster											
CLS-CLASS	218		Information	DVD player											
CLS-CLASS	218		Information	DTA - Mbrace or TELEAID/GPS Box											
CLS-CLASS	218		Information	D-FOR - Display in right rear passenger											
CLS-CLASS	218		Information	D-FOL - Display in left rear passenger											
CLS-CLASS	218		Information	DAB/SDAR - Digital/Satellite radio											
CLS-CLASS	218		Information	CTEL/TEL - Cellular/Mobile telephone											
CLS-CLASS	218		Information	COU [ZBE] - Audio/COMAND operating unit											
CLS-CLASS	218		Information	AUDIO/COMAND											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
CLS-CLASS	218		Seat/Door	PSD/MSC - Sliding roof control											
CLS-CLASS	218		Seat/Door	HKS - Tailgate control											
CLS-CLASS	218		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
CLS-CLASS	218		Seat/Door	ESA Driver - Electric seat adjustment Driver											
CLS-CLASS	218		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
CLS-CLASS	218		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
CLS-CLASS	218		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
CLS-CLASS	218		Seat/Door	DCM-RR - Door control module rear right											
CLS-CLASS	218		Seat/Door	DCM-RL - Door control module rear left											
CLS-CLASS	218		Seat/Door	DCM-FR - Door control module front right											
CLS-CLASS	218		Seat/Door	DCM-FL - Door control module front left											
CLS-CLASS	218		Air Conditioning	TSTH/STH - Stationary heater with remote control											
CLS-CLASS	218		Air Conditioning	AAC - Automatic air conditioning											
CL-CLASS	215		Drive	ME/CDI/CNG - Engine control unit											
CL-CLASS	215		Drive	ETC - Electronic transmission control											
CL-CLASS	215		Drive	ESM - Electronic selector module											
CL-CLASS	215		Drive	DTR - Distronic											
CL-CLASS	215		Chassis	ABS/ESP - Electronic stability program											
CL-CLASS	215		Chassis	Suspension											
CL-CLASS	215		Chassis	PSE - Pneumatic system equipment											
CL-CLASS	215		Chassis	TPM - Tire pressure monitor											
CL-CLASS	215		Body	UCP - Upper control panel											
CL-CLASS	215		Body	System diagnosis											
CL-CLASS	215		Body	SCM [MRM] - Steering column module											
CL-CLASS	215		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
CL-CLASS	215		Body	SAM-P- Passenger-side signal acquisition and actuation module											
CL-CLASS	215		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
CL-CLASS	215		Body	RCM - Rear control module											
CL-CLASS	215		Body	OCP - Overhead control panel											
CL-CLASS	215		Body	Multifunction control unit											
CL-CLASS	215		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
CL-CLASS	215		Body	HSW/LRH - Steering wheel heater											
CL-CLASS	215		Body	Headlamp-R - Headlamp control unit											
CL-CLASS	215		Body	Headlamp/Headlamp-L - Headlamp control unit											V
CL-CLASS	215		Body	EZS/EIS - Electronic ignition lock											
CL-CLASS	215		Body	CGW - Central gateway											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
CL-CLASS	215		Body	AHE - Trailer recognition											
CL-CLASS	215		Body	AB - Airbag											
CL-CLASS	215		Information	TV - TV tuner											
CL-CLASS	215		Information	PTS - Parktronic system											
CL-CLASS	215		Information	NAV - Navigation module											
CL-CLASS	215		Information	IC - Instrument cluster				V							
CL-CLASS	215		Information	DTA - Mbrace or TELEAID/GPS Box		V									
CL-CLASS	215		Information	AUDIO/COMAND											
CL-CLASS	215		Information	AGW - Audio gateway											
CL-CLASS	215		Seat/Door	OSB-FR - Multicontour backrest front right											
CL-CLASS	215		Seat/Door	OSB-FL - Multicontour backrest front left											
CL-CLASS	215		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
CL-CLASS	215		Seat/Door	ESA Driver - Electric seat adjustment Driver											
CL-CLASS	215		Seat/Door	DCM-FR - Door control module front right											
CL-CLASS	215		Seat/Door	DCM-FL - Door control module front left											
CL-CLASS	215		Air Conditioning	TSTH/STH - Stationary heater with remote control											
CL-CLASS	215		Air Conditioning	KBE-H/REAR AC - Rear air conditioning											
CL-CLASS	215		Air Conditioning	AAC - Automatic air conditioning											
CL-CLASS	216		Drive	ME/CDI/CNG - Engine control unit								V	V		
CL-CLASS	216		Drive	ETC - Electronic transmission control											
CL-CLASS	216		Drive	ISM - Intelligent servo module	V										
CL-CLASS	216		Drive	FSCU/FSCU-L - Control unit Fuel pump											
CL-CLASS	216		Drive	DTR - Distronic											
CL-CLASS	216		Chassis	ABS/ESP - Electronic stability program											
CL-CLASS	216		Chassis	Suspension											
CL-CLASS	216		Chassis	ES - Electrical power steering											
CL-CLASS	216		Chassis	EFB - Electric parking brake											
CL-CLASS	216		Chassis	TPM - Tire pressure monitor						V	V				
CL-CLASS	216		Body	WSS - Weight sensing system											
CL-CLASS	216		Body	UCP - Upper control panel											
CL-CLASS	216		Body	System diagnosis											
CL-CLASS	216		Body	SCM [MRM] - Steering column module											
CL-CLASS	216		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
CL-CLASS	216		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
CL-CLASS	216		Body	RCM - Rear control module											
CL-CLASS	216		Body	OCP - Overhead control panel											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
CL-CLASS	216		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
CL-CLASS	216		Body	Headlamp-R - Headlamp control unit											
CL-CLASS	216		Body	Headlamp/Headlamp-L - Headlamp control unit											V
CL-CLASS	216		Body	EZS/EIS - Electronic ignition lock											
CL-CLASS	216		Body	CGW - Central gateway											
CL-CLASS	216		Body	BNS/BMS - Battery sensor											
CL-CLASS	216		Body	AHE - Trailer recognition											
CL-CLASS	216		Body	AB - Airbag											
CL-CLASS	216		Information	ZAN - Audio/COMAND display											
CL-CLASS	216		Information	VCS - Voice control											
CL-CLASS	216		Information	TV - TV tuner											
CL-CLASS	216		Information	Tuner - Standard tuner											
CL-CLASS	216		Information	SGR - Radar sensors control unit											
CL-CLASS	216		Information	MFK - Multifunction camera											
CL-CLASS	216		Information	RFK - Backup camera											
CL-CLASS	216		Information	PTS - Parktronic system											
CL-CLASS	216		Information	NSA - Night View Assist											
CL-CLASS	216		Information	NBR-LF - Left front range radar											
CL-CLASS	216		Information	NAV - Navigation module											
CL-CLASS	216		Information	MIF/UCI - Media interface											
CL-CLASS	216		Information	ICI - InCar Internet											
CL-CLASS	216		Information	IC - Instrument cluster											
CL-CLASS	216		Information	DTA - Mbrace or TELEAID/GPS Box											
CL-CLASS	216		Information	DAB/SDAR - Digital/Satellite radio											
CL-CLASS	216		Information	COU [ZBE] - Audio/COMAND operating unit											
CL-CLASS	216		Information	AUDIO/COMAND											
CL-CLASS	216		Information	ASSYST PLUS - PLUS Active Service System											
CL-CLASS	216		Information	ASSYST Active Service System											
CL-CLASS	216		Seat/Door	TLC/GTO - Garage door opener											
CL-CLASS	216		Seat/Door	HKS - Tailgate control											
CL-CLASS	216		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
CL-CLASS	216		Seat/Door	ESA Driver - Electric seat adjustment Driver											
CL-CLASS	216		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
CL-CLASS	216		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
CL-CLASS	216		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
CL-CLASS	216		Seat/Door	DCM-FR - Door control module front right											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
CL-CLASS	216		Seat/Door	DCM-FL - Door control module front left											
CL-CLASS	216		Air Conditioning	TSTH/STH - Stationary heater with remote control											
CL-CLASS	216		Air Conditioning	AAC - Automatic air conditioning											
CL-CLASS	217		Drive	SCR - Selective catalytic reduction			V								
CL-CLASS	217		Drive	SG-EM - Power electronics											
CL-CLASS	217		Drive	FSCU/FSCU-L - Control unit Fuel pump											
CL-CLASS	217		Drive	DTR - Distronic											
CL-CLASS	217		Drive	ISM - Intelligent servo module	V										
CL-CLASS	217		Drive	ME/CDI/CNG - Engine control unit								V	V		
CL-CLASS	217		Drive	ETC - Electronic transmission control											
CL-CLASS	217		Drive	PTCU - Common powertrain controller											
CL-CLASS	217		Chassis	TPM - Tire pressure monitor											
CL-CLASS	217		Chassis	ABS/ESP - Electronic stability program											
CL-CLASS	217		Chassis	ES - Electrical power steering											
CL-CLASS	217		Chassis	Suspension											
CL-CLASS	217		Chassis	EFB - Electric parking brake											
CL-CLASS	217		Information	TPAD - Touchpad											
CL-CLASS	217		Information	DAB/SDAR - Digital/Satellite radio											
CL-CLASS	217		Information	360' - Camera											
CL-CLASS	217		Information	SOUND - Sound system											
CL-CLASS	217		Information	RFK - Backup camera											
CL-CLASS	217		Information	SGR - Radar sensors control unit											
CL-CLASS	217		Information	PTS - Parktronic system											
CL-CLASS	217		Information	NSA - Night View Assist											
CL-CLASS	217		Information	NBR-LR/IRS-HLA - Left rear range radar											
CL-CLASS	217		Information	NBR-RR/IRS-HRA - Right rear range radar											
CL-CLASS	217		Information	NBR-RF - Right front range radar											
CL-CLASS	217		Information	NBR-LF - Left front range radar											
CL-CLASS	217		Information	MFK - Multifunction camera											
CL-CLASS	217		Information	Head-up display											
CL-CLASS	217		Information	AUDIO/COMAND											
CL-CLASS	217		Information	ZAN - Audio/COMAND display											
CL-CLASS	217		Information	COU [ZBE] - Audio/COMAND operating unit											
CL-CLASS	217		Information	KAB - Camera cover											
CL-CLASS	217		Information	IC - Instrument cluster											
CL-CLASS	217		Information	DTA - Mbrace or TELEAID/GPS Box											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
CL-CLASS	217		Body	ATA - ATA [EDW]/tow-away/interior protection											
CL-CLASS	217		Body	SCM [MRM] - Steering column module											
CL-CLASS	217		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
CL-CLASS	217		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
CL-CLASS	217		Body	AB - Airbag											
CL-CLASS	217		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
CL-CLASS	217		Body	Headlamp-R - Headlamp control unit											
CL-CLASS	217		Body	Headlamp/Headlamp-L - Headlamp control unit											V
CL-CLASS	217		Body	SG-AWF - Collision prevention assist											
CL-CLASS	217		Body	EZS/EIS - Electronic ignition lock											
CL-CLASS	217		Body	BNS/BMS - Battery sensor											
CL-CLASS	217		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
CL-CLASS	217		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
CL-CLASS	217		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
CL-CLASS	217		Seat/Door	ESA Driver - Electric seat adjustment Driver											
CL-CLASS	217		Seat/Door	HKS - Tailgate control											
CL-CLASS	217		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
CL-CLASS	217		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
CL-CLASS	217		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
CL-CLASS	217		Seat/Door	PSD/MSC - Sliding roof control											
CL-CLASS	217		Seat/Door	DCM-FR - Door control module front right											
CL-CLASS	217		Seat/Door	DCM-FL - Door control module front left											
CL-CLASS	217		Seat/Door	RVC/VDS - Convertible roof control											
CL-CLASS	217		Air Conditioning	AAC - Automatic air conditioning											
SLK-CLASS	170		Drive	ME/CDI/CNG - Engine control unit											
SLK-CLASS	170		Drive	ETC - Electronic transmission control											
SLK-CLASS	170		Drive	ESM - Electronic selector module											
SLK-CLASS	170		Chassis	ABS/ESP - Electronic stability program											
SLK-CLASS	170		Chassis	VP - Vacuum pump brake booster											
SLK-CLASS	170		Chassis	BAS - Brake assist											
SLK-CLASS	170		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
SLK-CLASS	170		Body	AB - Airbag											
SLK-CLASS	170		Information	IC - Instrument cluster				V							
SLK-CLASS	170		Information	DTA - Mbrace or TELEAID/GPS Box		V									
SLK-CLASS	170		Information	AUDIO/COMAND											
SLK-CLASS	170		Air Conditioning	TSTH/STH - Stationary heater with remote control											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
SLK-CLASS	170		Air Conditioning	AAC - Automatic air conditioning											
SLK-CLASS	171		Drive	ME/CDI/CNG - Engine control unit											
SLK-CLASS	171		Drive	ETC - Electronic transmission control											
SLK-CLASS	171		Drive	ESM - Electronic selector module											
SLK-CLASS	171		Chassis	ABS/ESP - Electronic stability program											
SLK-CLASS	171		Chassis	TPM - Tire pressure monitor											
SLK-CLASS	171		Body	WSS - Weight sensing system										V	
SLK-CLASS	171		Body	UCP - Upper control panel											
SLK-CLASS	171		Body	System diagnosis											
SLK-CLASS	171		Body	SCM [MRM] - Steering column module											
SLK-CLASS	171		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
SLK-CLASS	171		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
SLK-CLASS	171		Body	OCP - Overhead control panel					V						
SLK-CLASS	171		Body	Headlamp/Headlamp-L - Headlamp control unit											
SLK-CLASS	171		Body	EZS/EIS - Electronic ignition lock											
SLK-CLASS	171		Body	CGW - Central gateway											
SLK-CLASS	171		Body	AB - Airbag											
SLK-CLASS	171		Information	TV - TV tuner											
SLK-CLASS	171		Information	SOUND - Sound system											
SLK-CLASS	171		Information	PTS - Parktronic system											
SLK-CLASS	171		Information	MIF/UCI - Media interface											
SLK-CLASS	171		Information	IC - Instrument cluster				V							
SLK-CLASS	171		Information	DTA - Mbrace or TELEAID/GPS Box											
SLK-CLASS	171		Information	DAB/SDAR - Digital/Satellite radio											
SLK-CLASS	171		Information	CTEL/TEL - Cellular/Mobile telephone											
SLK-CLASS	171		Information	AUDIO/COMAND											
SLK-CLASS	171		Information	ASSYST PLUS - PLUS Active Service System											
SLK-CLASS	171		Information	ASSYST Active Service System											
SLK-CLASS	171		Information	AGW - Audio gateway											
SLK-CLASS	171		Seat/Door	RVC/VDS - Convertible roof control											
SLK-CLASS	171		Seat/Door	HS - Seat heater											
SLK-CLASS	171		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
SLK-CLASS	171		Seat/Door	ESA Driver - Electric seat adjustment Driver											
SLK-CLASS	171		Seat/Door	DCM-FR - Door control module front right											
SLK-CLASS	171		Seat/Door	DCM-FL - Door control module front left											
SLK-CLASS	171		Air Conditioning	AAC - Automatic air conditioning											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
SLK-CLASS	172		Drive	ME/CDI/CNG - Engine control unit								V	V		
SLK-CLASS	172		Drive	ETC - Electronic transmission control											
SLK-CLASS	172		Drive	ESM - Electronic selector module											
SLK-CLASS	172		Drive	DTR - Distronic											
SLK-CLASS	172		Drive	FSCU/FSCU-L - Control unit Fuel pump											
SLK-CLASS	172		Chassis	ABS/ESP - Electronic stability program											
SLK-CLASS	172		Chassis	Suspension											
SLK-CLASS	172		Chassis	ES - Electrical power steering											
SLK-CLASS	172		Chassis	EFB - Electric parking brake											
SLK-CLASS	172		Chassis	TPM - Tire pressure monitor						V	V				
SLK-CLASS	172		Body	SCM [MRM] - Steering column module											
SLK-CLASS	172		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
SLK-CLASS	172		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
SLK-CLASS	172		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
SLK-CLASS	172		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
SLK-CLASS	172		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
SLK-CLASS	172		Body	HS/AIRSCARF - Seat heater/Air scarf system											
SLK-CLASS	172		Body	Headlamp/Headlamp-L - Headlamp control unit											V
SLK-CLASS	172		Body	EZS/EIS - Electronic ignition lock											
SLK-CLASS	172		Body	CGW - Central gateway											
SLK-CLASS	172		Body	AB - Airbag											
SLK-CLASS	172		Information	Drive Kit Plus - Drive kit for iPhone(R)											
SLK-CLASS	172		Information	ZAN - Audio/COMAND display											
SLK-CLASS	172		Information	TV - TV tuner											
SLK-CLASS	172		Information	SOUND - Sound system											
SLK-CLASS	172		Information	SGR - Radar sensors control unit											
SLK-CLASS	172		Information	MFK - Multifunction camera											
SLK-CLASS	172		Information	PTS - Parktronic system											
SLK-CLASS	172		Information	NBR-RR/IRS-HRA - Right rear range radar											
SLK-CLASS	172		Information	NBR-RF - Right front range radar											
SLK-CLASS	172		Information	NBR-LR/IRS-HLA - Left rear range radar											
SLK-CLASS	172		Information	NBR-LF - Left front range radar											
SLK-CLASS	172		Information	NAV - Navigation module											
SLK-CLASS	172		Information	MIF/UCI - Media interface											
SLK-CLASS	172		Information	IC - Instrument cluster											
SLK-CLASS	172		Information	DTA - Mbrace or TELEAID/GPS Box											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
SLK-CLASS	172		Information	DAB/SDAR - Digital/Satellite radio											
SLK-CLASS	172		Information	COU [ZBE] - Audio/COMAND operating unit											
SLK-CLASS	172		Information	AUDIO/COMAND											
SLK-CLASS	172		Seat/Door	RVC/VDS - Convertible roof control											
SLK-CLASS	172		Seat/Door	PSD/MSC - Sliding roof control											
SLK-CLASS	172		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
SLK-CLASS	172		Seat/Door	ESA Driver - Electric seat adjustment Driver											
SLK-CLASS	172		Seat/Door	DCM-FR - Door control module front right											
SLK-CLASS	172		Seat/Door	DCM-FL - Door control module front left											
SLK-CLASS	172		Air Conditioning	AAC - Automatic air conditioning											
SL-CLASS	129		Drive	ME/CDI/CNG - Engine control unit											
SL-CLASS	129		Drive	ETC - Electronic transmission control											
SL-CLASS	129		Chassis	ABS/ESP - Electronic stability program											
SL-CLASS	129		Chassis	BAS - Brake assist											
SL-CLASS	129		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
SL-CLASS	129		Body	AB - Airbag											
SL-CLASS	129		Information	NAV - Navigation module											
SL-CLASS	129		Information	IC - Instrument cluster				V							
SL-CLASS	129		Information	DTA - Mbrace or TELEAID/GPS Box		V									
SL-CLASS	129		Information	AUDIO/COMAND											
SL-CLASS	129		Information	APS - Auto pilot system											
SL-CLASS	129		Air Conditioning	TSTH/STH - Stationary heater with remote control											
SL-CLASS	129		Air Conditioning	AAC - Automatic air conditioning											
SL-CLASS	230		Drive	ME/CDI/CNG - Engine control unit											
SL-CLASS	230		Drive	ETC - Electronic transmission control											
SL-CLASS	230		Drive	ESM - Electronic selector module											
SL-CLASS	230		Drive	DTR - Distronic											
SL-CLASS	230		Drive	AMG DRIVE UNIT											
SL-CLASS	230		Chassis	ABS/ESP - Electronic stability program											
SL-CLASS	230		Chassis	Suspension											
SL-CLASS	230		Chassis	SBC - Sensotronic Brake Control											
SL-CLASS	230		Chassis	PSE - Pneumatic system equipment											
SL-CLASS	230		Chassis	HS/AIRSCARF - Seat heater/Air scarf system											
SL-CLASS	230		Chassis	TPM - Tire pressure monitor											
SL-CLASS	230		Body	WSS - Weight sensing system										V	
SL-CLASS	230		Body	System diagnosis											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
SL-CLASS	230		Body	SCM [MRM] - Steering column module											
SL-CLASS	230		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
SL-CLASS	230		Body	SAM-P- Passenger-side signal acquisition and actuation module											
SL-CLASS	230		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
SL-CLASS	230		Body	OCP - Overhead control panel											
SL-CLASS	230		Body	LCP/HBF - Lower/Rear control panel											
SL-CLASS	230		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
SL-CLASS	230		Body	HSW/LRH - Steering wheel heater											
SL-CLASS	230		Body	Headlamp-R - Headlamp control unit											
SL-CLASS	230		Body	Headlamp/Headlamp-L - Headlamp control unit											V
SL-CLASS	230		Body	EZS/EIS - Electronic ignition lock											
SL-CLASS	230		Body	CGW - Central gateway											
SL-CLASS	230		Body	BNS/BMS - Battery sensor											
SL-CLASS	230		Body	AB - Airbag											
SL-CLASS	230		Information	TV - TV tuner											
SL-CLASS	230		Information	SOUND - Sound system											
SL-CLASS	230		Information	PTS - Parktronic system											
SL-CLASS	230		Information	MIF/UCI - Media interface											
SL-CLASS	230		Information	IC - Instrument cluster				V							
SL-CLASS	230		Information	DTA - Mbrace or TELEAID/GPS Box		V									
SL-CLASS	230		Information	DAB/SDAR - Digital/Satellite radio											
SL-CLASS	230		Information	CTEL/TEL - Cellular/Mobile telephone											
SL-CLASS	230		Information	AUDIO/COMAND											
SL-CLASS	230		Information	AGW - Audio gateway											
SL-CLASS	230		Seat/Door	RVC/VDS - Convertible roof control											
SL-CLASS	230		Seat/Door	OSB-FR - Multicontour backrest front right											
SL-CLASS	230		Seat/Door	OSB-FL - Multicontour backrest front left											
SL-CLASS	230		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
SL-CLASS	230		Seat/Door	ESA Driver - Electric seat adjustment Driver											
SL-CLASS	230		Seat/Door	DCM-FR - Door control module front right											
SL-CLASS	230		Seat/Door	DCM-FL - Door control module front left											
SL-CLASS	230		Air Conditioning	TSTH/STH - Stationary heater with remote control											
SL-CLASS	230		Air Conditioning	AAC - Automatic air conditioning											
SL-CLASS	231		Drive	ME/CDI/CNG - Engine control unit								V	V		
SL-CLASS	231		Drive	ETC - Electronic transmission control											
SL-CLASS	231		Drive	ISM - Intelligent servo module	V										

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
SL-CLASS	231		Drive	FSCU/FSCU-L - Control unit Fuel pump											
SL-CLASS	231		Drive	DTR - Distronic											
SL-CLASS	231		Drive	DSI - Direct select interface											
SL-CLASS	231		Drive	AMG DRIVE UNIT											
SL-CLASS	231		Chassis	ABS/ESP - Electronic stability program											
SL-CLASS	231		Chassis	Suspension											
SL-CLASS	231		Chassis	ES - Electrical power steering											
SL-CLASS	231		Chassis	EFB - Electric parking brake											
SL-CLASS	231		Chassis	FWGW - Chassis gateway											
SL-CLASS	231		Chassis	TPM - Tire pressure monitor						V	V				
SL-CLASS	231		Body	SCM [MRM] - Steering column module											
SL-CLASS	231		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
SL-CLASS	231		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
SL-CLASS	231		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
SL-CLASS	231		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
SL-CLASS	231		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
SL-CLASS	231		Body	HS/AIRSCARF - Seat heater/Air scarf system											
SL-CLASS	231		Body	Headlamp/Headlamp-L - Headlamp control unit											V
SL-CLASS	231		Body	EZS/EIS - Electronic ignition lock											
SL-CLASS	231		Body	CGW - Central gateway											
SL-CLASS	231		Body	AB - Airbag											
SL-CLASS	231		Information	Drive Kit Plus - Drive kit for iPhone(R)											
SL-CLASS	231		Information	ZAN - Audio/COMAND display											
SL-CLASS	231		Information	TV - TV tuner											
SL-CLASS	231		Information	SOUND - Sound system											
SL-CLASS	231		Information	SGR - Radar sensors control unit											
SL-CLASS	231		Information	RFK - Backup camera											
SL-CLASS	231		Information	MFK - Multifunction camera											
SL-CLASS	231		Information	PTS - Parktronic system											
SL-CLASS	231		Information	NSA - Night View Assist											
SL-CLASS	231		Information	NBR-RR/IRS-HRA - Right rear range radar											
SL-CLASS	231		Information	NBR-RF - Right front range radar											
SL-CLASS	231		Information	NBR-LR/IRS-HLA - Left rear range radar											
SL-CLASS	231		Information	NBR-LF - Left front range radar											
SL-CLASS	231		Information	MIF/UCI - Media interface											
SL-CLASS	231		Information	IC - Instrument cluster											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
SL-CLASS	231		Information	DTA - Mbrace or TELEAID/GPS Box											
SL-CLASS	231		Information	DAB/SDAR - Digital/Satellite radio											
SL-CLASS	231		Information	COU [ZBE] - Audio/COMAND operating unit											
SL-CLASS	231		Information	AUDIO/COMAND											
SL-CLASS	231		Information	AMG Performance Media											
SL-CLASS	231		Seat/Door	RVC/VDS - Convertible roof control											
SL-CLASS	231		Seat/Door	PSD/MSC - Sliding roof control											
SL-CLASS	231		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
SL-CLASS	231		Seat/Door	ESA Driver - Electric seat adjustment Driver											
SL-CLASS	231		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
SL-CLASS	231		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
SL-CLASS	231		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
SL-CLASS	231		Seat/Door	DCM-FR - Door control module front right											
SL-CLASS	231		Seat/Door	DCM-FL - Door control module front left											
SL-CLASS	231		Air Conditioning	AAC - Automatic air conditioning											
SLS-CLASS	197		Drive	PTCU - Common powertrain controller											
SLS-CLASS	197		Drive	ME/CDI/CNG - Engine control unit											
SLS-CLASS	197		Drive	ETC - Electronic transmission control											
SLS-CLASS	197		Drive	ISM - Intelligent servo module	V										
SLS-CLASS	197		Drive	FSCU/FSCU-L - Control unit Fuel pump											
SLS-CLASS	197		Drive	DSI - Direct select interface											
SLS-CLASS	197		Drive	AMG DRIVE UNIT											
SLS-CLASS	197		Chassis	ABS/ESP - Electronic stability program											
SLS-CLASS	197		Chassis	Suspension											
SLS-CLASS	197		Chassis	ES - Electrical power steering											
SLS-CLASS	197		Chassis	EFB - Electric parking brake											
SLS-CLASS	197		Chassis	TPM - Tire pressure monitor						V	V				
SLS-CLASS	197		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
SLS-CLASS	197		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
SLS-CLASS	197		Body	CSHV - Crash sensor/high-voltage battery											
SLS-CLASS	197		Body	BNS/BMS - Battery sensor			V					V	V		
SLS-CLASS	197		Body	WSS - Weight sensing system											
SLS-CLASS	197		Body	SCM [MRM] - Steering column module											
SLS-CLASS	197		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
SLS-CLASS	197		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
SLS-CLASS	197		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
SLS-CLASS	197		Body	HS/AIRSCARF - Seat heater/Air scarf system											
SLS-CLASS	197		Body	EZS/EIS - Electronic ignition lock											
SLS-CLASS	197		Body	CGW - Central gateway											
SLS-CLASS	197		Body	AB - Airbag											
SLS-CLASS	197		Information	MFK - Multifunction camera											
SLS-CLASS	197		Information	SGR - Radar sensors control unit											
SLS-CLASS	197		Information	ZAN - Audio/COMAND display											
SLS-CLASS	197		Information	SOUND - Sound system											
SLS-CLASS	197		Information	PTS - Parktronic system											
SLS-CLASS	197		Information	NBR-RR/IRS-HRA - Right rear range radar											
SLS-CLASS	197		Information	NBR-LR/IRS-HLA - Left rear range radar											
SLS-CLASS	197		Information	MIF/UCI - Media interface											
SLS-CLASS	197		Information	IC - Instrument cluster											
SLS-CLASS	197		Information	DTA - Mbrace or TELEAID/GPS Box											
SLS-CLASS	197		Information	DAB/SDAR - Digital/Satellite radio											
SLS-CLASS	197		Information	COU [ZBE] - Audio/COMAND operating unit											
SLS-CLASS	197		Information	AUDIO/COMAND											
SLS-CLASS	197		Information	AMG Performance Media											
SLS-CLASS	197		Seat/Door	RVC/VDS - Convertible roof control											
SLS-CLASS	197		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
SLS-CLASS	197		Seat/Door	ESA Driver - Electric seat adjustment Driver											
SLS-CLASS	197		Seat/Door	DCM-FR - Door control module front right											
SLS-CLASS	197		Seat/Door	DCM-FL - Door control module front left											
SLS-CLASS	197		Air Conditioning	AAC - Automatic air conditioning											
AMG GT	190		Drive	DTR - Distronic											
AMG GT	190		Drive	FSCU/FSCU-L - Control unit Fuel pump											
AMG GT	190		Drive	DSI - Direct select interface											
AMG GT	190		Drive	AMG DRIVE UNIT											
AMG GT	190		Drive	PTCU - Common powertrain controller											
AMG GT	190		Drive	ME/CDI/CNG - Engine control unit								V	V		
AMG GT	190		Drive	ETC - Electronic transmission control											
AMG GT	190		Chassis	TPM - Tire pressure monitor											
AMG GT	190		Chassis	Suspension											
AMG GT	190		Chassis	ABS/ESP - Electronic stability program											
AMG GT	190		Chassis	EFB - Electric parking brake											
AMG GT	190		Information	TPAD - Touchpad											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
AMG GT	190		Information	DAB/SDAR - Digital/Satellite radio											
AMG GT	190		Information	SOUND - Sound system											
AMG GT	190		Information	RFK - Backup camera											
AMG GT	190		Information	PTS - Parktronic system											
AMG GT	190		Information	MFK - Multifunction camera											
AMG GT	190		Information	IC - Instrument cluster											
AMG GT	190		Information	NBR-LR/IRS-HLA - Left rear range radar											
AMG GT	190		Information	NBR-RR/IRS-HRA - Right rear range radar											
AMG GT	190		Information	AUDIO/COMAND											
AMG GT	190		Information	ZAN - Audio/COMAND display											
AMG GT	190		Information	COU [ZBE] - Audio/COMAND operating unit											
AMG GT	190		Information	DTA - Mbrace or TELEAID/GPS Box											
AMG GT	190		Information	AMG Performance Media											
AMG GT	190		Body	SCM [MRM] - Steering column module											
AMG GT	190		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
AMG GT	190		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
AMG GT	190		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
AMG GT	190		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
AMG GT	190		Body	AB - Airbag											
AMG GT	190		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
AMG GT	190		Body	Headlamp-R - Headlamp control unit											
AMG GT	190		Body	Headlamp/Headlamp-L - Headlamp control unit											V
AMG GT	190		Body	SG-AWF - Collision prevention assist											
AMG GT	190		Body	EZS/EIS - Electronic ignition lock											
AMG GT	190		Body	CGW - Central gateway											
AMG GT	190		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
AMG GT	190		Seat/Door	ESA Driver - Electric seat adjustment Driver											
AMG GT	190		Seat/Door	DCM-FR - Door control module front right											
AMG GT	190		Seat/Door	DCM-FL - Door control module front left											
AMG GT	190		Air Conditioning	AAC - Automatic air conditioning											
SLR-CLASS	199		Drive	ME/CDI/CNG - Engine control unit											
SLR-CLASS	199		Drive	ETC - Electronic transmission control											
SLR-CLASS	199		Drive	ESM - Electronic selector module											
SLR-CLASS	199		Chassis	ABS/ESP - Electronic stability program											
SLR-CLASS	199		Chassis	SBC - Sensotronic Brake Control											
SLR-CLASS	199		Chassis	TPM - Tire pressure monitor											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
SLR-CLASS	199		Body	WSS - Weight sensing system										V	
SLR-CLASS	199		Body	SCM [MRM] - Steering column module											
SLR-CLASS	199		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
SLR-CLASS	199		Body	SAM-P- Passenger-side signal acquisition and actuation module											
SLR-CLASS	199		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
SLR-CLASS	199		Body	OCP - Overhead control panel											
SLR-CLASS	199		Body	LCP/HBF - Lower/Rear control panel											
SLR-CLASS	199		Body	Headlamp-R - Headlamp control unit											
SLR-CLASS	199		Body	Headlamp/Headlamp-L - Headlamp control unit											V
SLR-CLASS	199		Body	EZS/EIS - Electronic ignition lock											
SLR-CLASS	199		Body	CGW - Central gateway											
SLR-CLASS	199		Body	BNS/BMS - Battery sensor											
SLR-CLASS	199		Body	AB - Airbag											
SLR-CLASS	199		Information	IC - Instrument cluster				V							
SLR-CLASS	199		Information	DTA - Mbrace or TELEAID/GPS Box		V									
SLR-CLASS	199		Information	AUDIO/COMAND											
SLR-CLASS	199		Seat/Door	DCM-FR - Door control module front right											
SLR-CLASS	199		Seat/Door	DCM-FL - Door control module front left											
SLR-CLASS	199		Air Conditioning	AAC - Automatic air conditioning											
MAYBACH	240		Drive	ME/CDI/CNG - Engine control unit											
MAYBACH	240		Drive	ETC - Electronic transmission control											
MAYBACH	240		Drive	ESM - Electronic selector module											
MAYBACH	240		Drive	FSCU/FSCU-L - Control unit Fuel pump											
MAYBACH	240		Drive	DTR - Distronic	V	V	V	V	V	V	V	V	V	V	V
MAYBACH	240		Chassis	ABS/ESP - Electronic stability program											
MAYBACH	240		Chassis	Suspension											
MAYBACH	240		Chassis	SBC - Sensotronic Brake Control											
MAYBACH	240		Chassis	TPM - Tire pressure monitor											
MAYBACH	240		Body	WSS - Weight sensing system										V	
MAYBACH	240		Body	System diagnosis											
MAYBACH	240		Body	SCM [MRM] - Steering column module											
MAYBACH	240		Body	HSW/LRH - Steering wheel heater											
MAYBACH	240		Body	Headlamp/Headlamp-L - Headlamp control unit											
MAYBACH	240		Body	AB - Airbag											
MAYBACH	240		Information	TV - TV tuner											
MAYBACH	240		Information	PTS - Parktronic system											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
MAYBACH	240		Information	DTA - Mbrace or TELEAID/GPS Box											
MAYBACH	240		Information	AGW - Audio gateway											
MAYBACH	240		Seat/Door	REDC/RWT - Rear end door control module											
MAYBACH	240		Air Conditioning	TSTH/STH - Stationary heater with remote control											
All_Model(BETA)	16P Connector		Drive	SG-EM - Power electronics											
All_Model(BETA)	16P Connector		Drive	HFPM - Haptic accelerator pedal module											
All_Model(BETA)	16P Connector		Drive	ME/CDI/CNG - Engine control unit								V	V		
All_Model(BETA)	16P Connector		Drive	ETC - Electronic transmission control											
All_Model(BETA)	16P Connector		Drive	ESM - Electronic selector module											
All_Model(BETA)	16P Connector		Drive	VG - Transfer case											
All_Model(BETA)	16P Connector		Drive	VECU - Power monitoring control unit											
All_Model(BETA)	16P Connector		Drive	SG-EM-B - Electric motor control unit B											
All_Model(BETA)	16P Connector		Drive	SG-EM-A - Electric motor control unit A											
All_Model(BETA)	16P Connector		Drive	SCR - Selective catalytic reduction			V								
All_Model(BETA)	16P Connector		Drive	PTCU - Common powertrain controller											
All_Model(BETA)	16P Connector		Drive	Natural gas control unit											
All_Model(BETA)	16P Connector		Drive	ISM - Intelligent servo module	V										
All_Model(BETA)	16P Connector		Drive	Hydrogen tank control unit											
All_Model(BETA)	16P Connector		Drive	HSG - Hybrid control unit											
All_Model(BETA)	16P Connector		Drive	High-temperature coolant pump control unit											
All_Model(BETA)	16P Connector		Drive	Fuel cell control unit											
All_Model(BETA)	16P Connector		Drive	FSCU-R - Control unit fuel pump											
All_Model(BETA)	16P Connector		Drive	FSCU/FSCU-L - Control unit Fuel pump											
All_Model(BETA)	16P Connector		Drive	EMPI - Electronic Motor Pump Inverter											
All_Model(BETA)	16P Connector		Drive	Electric drive control unit											
All_Model(BETA)	16P Connector		Drive	DTR - Distronic											
All_Model(BETA)	16P Connector		Drive	DSI - Direct select interface											
All_Model(BETA)	16P Connector		Drive	Compressed Natural Gas Control Module											
All_Model(BETA)	16P Connector		Drive	CC - Cruise control											
All_Model(BETA)	16P Connector		Drive	BSA - Belt-driven starter/alternator											
All_Model(BETA)	16P Connector		Drive	AMG DRIVE UNIT											
All_Model(BETA)	16P Connector		Drive	ACS - Automatic clutch system											
All_Model(BETA)	16P Connector		Chassis	ABS/ESP - Electronic stability program											
All_Model(BETA)	16P Connector		Chassis	Suspension											
All_Model(BETA)	16P Connector		Chassis	SBC - Sensotronic Brake Control											
All_Model(BETA)	16P Connector		Chassis	PSE - Pneumatic system equipment											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
All_Model(BETA)	16P Connector		Chassis	HS/AIRSCARF - Seat heater/Air scarf system											
All_Model(BETA)	16P Connector		Chassis	HAQ - Interwheel differential lock at rear axle											
All_Model(BETA)	16P Connector		Chassis	FWGW - Chassis gateway											
All_Model(BETA)	16P Connector		Chassis	ES - Electrical power steering											
All_Model(BETA)	16P Connector		Chassis	EFB - Electric parking brake											
All_Model(BETA)	16P Connector		Chassis	BAS - Brake assist											
All_Model(BETA)	16P Connector		Chassis	VP - Vacuum pump brake booster											
All_Model(BETA)	16P Connector		Chassis	TPM - Tire pressure monitor						V	V				
All_Model(BETA)	16P Connector		Body	SG-LML-VR - LED matrix of right front lamp unit											
All_Model(BETA)	16P Connector		Body	SG-LML-VL - LED matrix of left front lamp unit											
All_Model(BETA)	16P Connector		Body	FLANFS - Fire extinguishing system and emergency fresh air system											
All_Model(BETA)	16P Connector		Body	CSHV - Crash sensor/high-voltage battery											
All_Model(BETA)	16P Connector		Body	WSS - Weight sensing system										V	
All_Model(BETA)	16P Connector		Body	UCP - Upper control panel											
All_Model(BETA)	16P Connector		Body	System diagnosis											
All_Model(BETA)	16P Connector		Body	SG-DDW - DC/DC converter control unit											
All_Model(BETA)	16P Connector		Body	SG-AWF - Collision prevention assist											
All_Model(BETA)	16P Connector		Body	SCM [MRM] - Steering column module											
All_Model(BETA)	16P Connector		Body	SAM-R/BSN - Rear signal acquisition and actuation module/Battery sensor											
All_Model(BETA)	16P Connector		Body	SAM-P- Passenger-side signal acquisition and actuation module											
All_Model(BETA)	16P Connector		Body	SAM-F/SAM-D - Signal acquisition and actuation module front/driver side											
All_Model(BETA)	16P Connector		Body	RevETR-RF - Right front reversible emergency tensioning retractor											
All_Model(BETA)	16P Connector		Body	RevETR-LF - Left front reversible emergency tensioning retractor											
All_Model(BETA)	16P Connector		Body	RCM - Rear control module											
All_Model(BETA)	16P Connector		Body	OCP - Overhead control panel					V						
All_Model(BETA)	16P Connector		Body	Multifunction control unit											
All_Model(BETA)	16P Connector		Body	LCP/HBF - Lower/Rear control panel											
All_Model(BETA)	16P Connector		Body	LAE [LAA] - Loading floor automatically extendable											
All_Model(BETA)	16P Connector		Body	KG/RFL - KEYLESS GO/Radio frequency locking/Electric central locking											
All_Model(BETA)	16P Connector		Body	HSW/LRH - Steering wheel heater											
All_Model(BETA)	16P Connector		Body	Headlamp-R - Headlamp control unit											
All_Model(BETA)	16P Connector		Body	Headlamp/Headlamp-L - Headlamp control unit											V
All_Model(BETA)	16P Connector		Body	EZS/EIS - Electronic ignition lock											
All_Model(BETA)	16P Connector		Body	CGW - Central gateway											
All_Model(BETA)	16P Connector		Body	BNS/BMS - Battery sensor											
All_Model(BETA)	16P Connector		Body	ATA - ATA [EDW]/tow-away/interior protection											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
All_Model(BETA)	16P Connector		Body	AHE - Trailer recognition											
All_Model(BETA)	16P Connector		Body	AB - Airbag											
All_Model(BETA)	16P Connector		Body	AAM - All activity module											
All_Model(BETA)	16P Connector		Information	TPAD - Touchpad											
All_Model(BETA)	16P Connector		Information	Head-up display											
All_Model(BETA)	16P Connector		Information	Drive Kit Plus - Drive kit for iPhone(R)											
All_Model(BETA)	16P Connector		Information	KAB - Camera cover											
All_Model(BETA)	16P Connector		Information	ZAN - Audio/COMAND display											
All_Model(BETA)	16P Connector		Information	VCS - Voice control											
All_Model(BETA)	16P Connector		Information	TV - TV tuner											
All_Model(BETA)	16P Connector		Information	Tuner - Standard tuner											
All_Model(BETA)	16P Connector		Information	Sound generator for exhaust system											
All_Model(BETA)	16P Connector		Information	SOUND - Sound system											
All_Model(BETA)	16P Connector		Information	SGR - Radar sensors control unit											
All_Model(BETA)	16P Connector		Information	360' - Camera											
All_Model(BETA)	16P Connector		Information	MFK - Multifunction camera											
All_Model(BETA)	16P Connector		Information	RFK - Backup camera											
All_Model(BETA)	16P Connector		Information	PTS - Parktronic system											
All_Model(BETA)	16P Connector		Information	NSA - Night View Assist											
All_Model(BETA)	16P Connector		Information	NBR-RR/IRS-HRA - Right rear range radar											
All_Model(BETA)	16P Connector		Information	NBR-RF - Right front range radar											
All_Model(BETA)	16P Connector		Information	NBR-LR/IRS-HLA - Left rear range radar											
All_Model(BETA)	16P Connector		Information	NBR-LF - Left front range radar											
All_Model(BETA)	16P Connector		Information	NAV - Navigation module											
All_Model(BETA)	16P Connector		Information	MIF/UCI - Media interface											
All_Model(BETA)	16P Connector		Information	ICI - InCar Internet											
All_Model(BETA)	16P Connector		Information	IC - Instrument cluster				V							
All_Model(BETA)	16P Connector		Information	DVD player											
All_Model(BETA)	16P Connector		Information	DTA - Mbrace or TELEAID/GPS Box		V									
All_Model(BETA)	16P Connector		Information	D-FOR - Display in right rear passenger											
All_Model(BETA)	16P Connector		Information	D-FOL - Display in left rear passenger											
All_Model(BETA)	16P Connector		Information	DAB/SDAR - Digital/Satellite radio											
All_Model(BETA)	16P Connector		Information	CTEL/TEL - Cellular/Mobile telephone											
All_Model(BETA)	16P Connector		Information	COU [ZBE] - Audio/COMAND operating unit											
All_Model(BETA)	16P Connector		Information	CM - Compass module											
All_Model(BETA)	16P Connector		Information	AVE-H - Rear audio video unit											

Series	Chassis	Type1	Type2	System	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
All Model(BETA)	16P Connector		Information	AUDIO/COMAND											
All Model(BETA)	16P Connector		Information	ASSYST PLUS - PLUS Active Service System											
All Model(BETA)	16P Connector		Information	ASSYST Active Service System											
All Model(BETA)	16P Connector		Information	APS - Auto pilot system											
All Model(BETA)	16P Connector		Information	AMG Performance Media											
All Model(BETA)	16P Connector		Information	AGW - Audio gateway											
All Model(BETA)	16P Connector		Seat/Door	Right rear ESE - Right electrical seat adjustment											
All Model(BETA)	16P Connector		Seat/Door	Left rear ESE - Left electrical seat adjustment											
All Model(BETA)	16P Connector		Seat/Door	DS-RR/AMKS-RR - Dynamic/Active seat											
All Model(BETA)	16P Connector		Seat/Door	DS-LR/AMKS-LR - Dynamic/Active seat											
All Model(BETA)	16P Connector		Seat/Door	TSG-MR - Right center door control unit											
All Model(BETA)	16P Connector		Seat/Door	TSG-ML - Left center door control unit											
All Model(BETA)	16P Connector		Seat/Door	TLC/GTO - Garage door opener											
All Model(BETA)	16P Connector		Seat/Door	RVC/VDS - Convertible roof control											
All Model(BETA)	16P Connector		Seat/Door	REDC/RWT - Rear end door control module											
All Model(BETA)	16P Connector		Seat/Door	PSD/MSC - Sliding roof control											
All Model(BETA)	16P Connector		Seat/Door	OSB-R - Multicontour backrest rear											
All Model(BETA)	16P Connector		Seat/Door	OSB-FR - Multicontour backrest front right											
All Model(BETA)	16P Connector		Seat/Door	OSB-FL - Multicontour backrest front left											
All Model(BETA)	16P Connector		Seat/Door	MKL-HR - Rear right multicontour backrest											
All Model(BETA)	16P Connector		Seat/Door	MKL-HL - Rear left multicontour backrest											
All Model(BETA)	16P Connector		Seat/Door	HS - Seat heater											
All Model(BETA)	16P Connector		Seat/Door	HKS - Tailgate control											
All Model(BETA)	16P Connector		Seat/Door	ESA-R - Electric seat adjustment rear											
All Model(BETA)	16P Connector		Seat/Door	ESA Front passenger - Electric seat adjustment Front passenger											
All Model(BETA)	16P Connector		Seat/Door	ESA Driver - Electric seat adjustment Driver											
All Model(BETA)	16P Connector		Seat/Door	ERA - Electric fold down backrest system											
All Model(BETA)	16P Connector		Seat/Door	DS-RF/AMKS-RF - Dynamic/Active seat											
All Model(BETA)	16P Connector		Seat/Door	DSP/PPAMKS - Pneumatic pump for seat											
All Model(BETA)	16P Connector		Seat/Door	DS-LF/AMKS-LF - Dynamic/Active seat											
All Model(BETA)	16P Connector		Seat/Door	DCM-RR - Door control module rear right											
All Model(BETA)	16P Connector		Seat/Door	DCM-RL - Door control module rear left											
All Model(BETA)	16P Connector		Seat/Door	DCM-FR - Door control module front right											
All Model(BETA)	16P Connector		Seat/Door	DCM-FL - Door control module front left											
All Model(BETA)	16P Connector		Air Conditioning	TSTH/STH - Stationary heater with remote control											
All Model(BETA)	16P Connector		Air Conditioning	KBE-H/REAR AC - Rear air conditioning											
All Model(BETA)	16P Connector		Air Conditioning	HBF - Rear control panel											
All Model(BETA)	16P Connector		Air Conditioning	HB - Heater booster											
All Model(BETA)	16P Connector		Air Conditioning	EKMK - Electric refrigerant compressor											
All Model(BETA)	16P Connector		Air Conditioning	AAC - Automatic air conditioning											

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function "Tire pressure loss warning"	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Engine	CDI3	V		V	V	V																	V																
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Chassis	ESP - Electronic stability program	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	EZS - Electronic ignition lock	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	AB - Airbag	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	UCP - Upper control panel	V		V	V	V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	SAM - Signal acquisition and actuation module	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FL - Door control module front left	V		V	V	V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FR - Door control module front right	V		V	V	V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Information	IC - Instrument cluster	V		V	V	V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	AAC - Automatic air conditioning	V		V	V	V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	PTC - Electric heater booster	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Engine	CDI4	V		V	V	V															V						V		V										
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ETC - Electronic transmission control	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ESM - Electronic selector module	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	ESP - Electronic stability program	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	Suspension	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	EZS - Electronic ignition lock	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	AB - Airbag	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	UCP - Upper control panel	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	SAM - Signal acquisition and actuation module	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FL - Door control module front left	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FR - Door control module front right	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	IC - Instrument cluster	V		V		V																										V							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	PTS - Parktronic system	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	AGW - Audio gateway	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	CDC - CD changer	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	AAC - Automatic air conditioning	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	KBE-H/REAR AC - Rear air conditioning	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	PTC - Electric heater booster	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Engine	CDID	V		V		V				V											V																			
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ETC - Electronic transmission control	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ESM - Electronic selector module	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	ESP - Electronic stability program	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	Suspension	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	EZS - Electronic ignition lock	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	AB - Airbag	V				V																																	

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function "Tire pressure loss warning"	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	UCP - Upper control panel	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	SAM - Signal acquisition and actuation module	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FL - Door control module front left	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FR - Door control module front right	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	IC - Instrument cluster	V		V		V																										V							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	PTS - Parktronic system	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	AGW - Audio gateway	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	CDC - CD changer	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	AAC - Automatic air conditioning	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	KBE-H/REAR AC - Rear air conditioning	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	PTC - Electric heater booster	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Engine	CDID2	V		V		V				V											V																			
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ETC - Electronic transmission control	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ESM - Electronic selector module	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	ESP - Electronic stability program	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	Suspension	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	EZS - Electronic ignition lock	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	AB - Airbag	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	UCP - Upper control panel	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	SAM - Signal acquisition and actuation module	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FL - Door control module front left	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FR - Door control module front right	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	IC - Instrument cluster	V		V		V																										V							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	PTS - Parktronic system	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	AGW - Audio gateway	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	CDC - CD changer	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	AAC - Automatic air conditioning	V		V		V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	KBE-H/REAR AC - Rear air conditioning	V				V																																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	PTC - Electric heater booster	V				V																																	
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Engine	CDI1	V		V		V																																	
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Auto Transaxle	ETC - Electronic transmission control	V		V	V	V										V																							
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	AB - Airbag	V		V		V																																	
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	KR - Wiper	V		V	V	V																																	
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Information	IC - Instrument cluster	V		V		V																																	
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Air Conditioning	AAC - Automatic air conditioning	V		V	V	V																																	
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Engine	Engine control unit	V		V		V																																	

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function "Tire pressure loss warning"	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Body	AB - Airbag	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Engine	CDI3	V		V	V	V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Chassis	ESP - Electronic stability program	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	EZS - Electronic ignition lock	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	AB - Airbag	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	UCP - Upper control panel	V		V	V	V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	SAM - Signal acquisition and actuation module	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FL - Door control module front left	V		V	V	V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FR - Door control module front right	V		V	V	V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Information	IC - Instrument cluster	V		V	V	V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	AAC - Automatic air conditioning	V		V	V	V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	PTC - Electric heater booster	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI4	Engine	CDI4	V		V	V	V														V						V													
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ETC - Electronic transmission control	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ESM - Electronic selector module	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI4	Chassis	ESP - Electronic stability program	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	EZS - Electronic ignition lock	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	AB - Airbag	V				V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SCM [MRM] - Steering column module	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	UCP - Upper control panel	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SAM - Signal acquisition and actuation module	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI4	Seat/Door	TSG - Door control module front driver side	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDI4	Information	IC - Instrument cluster	V		V		V																										V							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Air Conditioning	AAC - Automatic air conditioning	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID	Engine	CDID	V		V		V			V											V																			
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ETC - Electronic transmission control	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ESM - Electronic selector module	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID	Chassis	ESP - Electronic stability program	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	EZS - Electronic ignition lock	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	AB - Airbag	V				V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SCM [MRM] - Steering column module	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	UCP - Upper control panel	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SAM - Signal acquisition and actuation module	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID	Seat/Door	TSG - Door control module front driver side	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID	Information	IC - Instrument cluster	V		V		V																										V							
Sprinter	Sprinter 2006-Present[W906]	CDID	Air Conditioning	AAC - Automatic air conditioning	V		V		V																																	

Series	Chassis	Type1	Type2	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	A9 (Refrigerant compressor)	Acceleration of sensor rotor adaptation	Activate demo mode of exterior lights	Activate fuel pump	Activate function [Tire pressure loss warning]	Activate function tire pressure loss warning	Activate function "Tire pressure loss warning"	Activate system SBC	Activation of fuel pump	Adaptation data clear	Adaptation data reset	Adaptation of torque converter lockup clutch	Additional battery service mode	Adjustment of headlamps via diagnosis	Adjustment of injector injection quantities	Adjustment of injector injection quantity	Adjustment of injector quantities	Adjustment on temperature of heater booster	Advance odometer	Air cushion calibration	Air filter initialization	Air filter learned values reset	Air intake turbocharging initialization	Alarm siren : Reset coding	Assignment of control modules to plug connections	ASSYST SETTING	Assyst setting adjustment	B28/2 (DPF differential pressure sensor)	Backup camera calibration	Backup camera in passenger outside mirror calib.	BAS Brake assist in ESP	Bleeding of high pressure fuel circuit	Breaking in of refrigerant compressor
Sprinter	Sprinter 2006-Present[W906]	CDID2	Engine	CDID2	V		V		V				V										V																			
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ETC - Electronic transmission control	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ESM - Electronic selector module	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID2	Chassis	ESP - Electronic stability program	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	EZS - Electronic ignition lock	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	AB - Airbag	V				V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SCM [MRM] - Steering column module	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	UCP - Upper control panel	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SAM - Signal acquisition and actuation module	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID2	Seat/Door	TSG - Door control module front driver side	V		V		V																																	
Sprinter	Sprinter 2006-Present[W906]	CDID2	Information	IC - Instrument cluster	V		V		V																										V							
Sprinter	Sprinter 2006-Present[W906]	CDID2	Air Conditioning	AAC - Automatic air conditioning	V		V		V																																	
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Engine	CR	V		V	V	V																																	
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	ETC - Electronic transmission control	V				V																																	
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	SSG - Sprint shift transmission	V		V	V	V																																	
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ABS - Antilock braking system	V		V		V																																	
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ESP - Electronic stability program	V		V		V																																	
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	AB - Airbag	V				V																																	
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	ABW - Airbag with window airbag	V				V																																	
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	WSP - Immobilizer	V		V		V																																	
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Information	IC - Instrument cluster	V		V		V																																	

Series	Chassis	Type1	Type2	System	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Engine	CDI3																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	UCP - Upper control panel																												V										
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	AAC - Automatic air conditioning																											V											
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	PTC - Electric heater booster																											V											
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Engine	CDI4																						V																
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	AB - Airbag																V																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Engine	CDID																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	AB - Airbag																V																						

Series	Chassis	Type1	Type2	System	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Engine	CDID2																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	AB - Airbag																	V																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Engine	CDI1																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	KR - Wiper																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Engine	Engine control unit																																						

Series	Chassis	Type1	Type2	System	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Engine	CDI3																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	UCP - Upper control panel																												V										
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FL - Door control module front left																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FR - Door control module front right																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	AAC - Automatic air conditioning																											V											
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	PTC - Electric heater booster																											V											
Sprinter	Sprinter 2006-Present[W906]	CDI4	Engine	CDI4																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	AB - Airbag																V																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Engine	CDID																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	AB - Airbag																V																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Air Conditioning	AAC - Automatic air conditioning																																						

Series	Chassis	Type1	Type2	System	Breaking-in of refrigerant compressor	Calibrate ISM	Calibration of Acceleration sensor	Calibration of AdBlue fill level sensor	Calibration of Electric parking brake control unit	Calibration of EPS torque sensor	Calibration of intake valves	Calibration of long range radar sensor	Calibration of reversing camera	Calibration of separation valves	Calibration of steering angle sensor	Calibration of the plunger travel sensors	Calibration of yaw rate sensor for acceleration	Calibration reset	Camera calibration	Cancel fault interlock	Carry out control unit reset	Check of adjustment range of positioning motors	CO2 Setting	CO2 Setting for vehicle without TWC	Coding of speed-sensitive power steering	Coding of the close-via-tilt function	Common rail initialization	Compression test	Confirm overall maintenance	Confirmation of battery change	Control module initialization	Control module reset	Control unit replace	Control unit reset	Correction coding : Cylinder shutoff	Correction coding : Default initialization	Correction coding : Engine or air conditioning	Correction coding : Fuel quantity	Correction coding : Idle speed with gear engaged	Correction coding : Idle speed with P/N	Correction coding : Ignition	Correction coding : Smooth engine running
Sprinter	Sprinter 2006-Present[W906]	CDID2	Engine	CDID2																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	AB - Airbag																	V																					
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Engine	CR																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	SSG - Sprint shift transmission																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ABS - Antilock braking system																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	AB - Airbag																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	ABW - Airbag with window airbag																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	WSP - Immobilizer																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Information	IC - Instrument cluster																																						

Series	Chassis	Type1	Type2	System	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Engine	CDI3																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Chassis	ESP - Electronic stability program																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	EZS - Electronic ignition lock																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	AB - Airbag																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	UCP - Upper control panel																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	SAM - Signal acquisition and actuation module																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FL - Door control module front left																						V																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FR - Door control module front right																						V																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Information	IC - Instrument cluster																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	AAC - Automatic air conditioning																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	PTC - Electric heater booster																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Engine	CDI4																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ESM - Electronic selector module																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	ESP - Electronic stability program																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	Suspension																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	EZS - Electronic ignition lock																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	AB - Airbag																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	UCP - Upper control panel																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	SAM - Signal acquisition and actuation module																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FL - Door control module front left																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FR - Door control module front right																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	IC - Instrument cluster																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	PTS - Parktronic system																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	AGW - Audio gateway																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	CDC - CD changer																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	PTC - Electric heater booster																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Engine	CDID																													V										
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ETC - Electronic transmission control																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ESM - Electronic selector module																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	ESP - Electronic stability program																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	Suspension																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	EZS - Electronic ignition lock																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	AB - Airbag																																							

Series	Chassis	Type1	Type2	System	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	UCP - Upper control panel																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	SAM - Signal acquisition and actuation module																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FL - Door control module front left																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FR - Door control module front right																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	IC - Instrument cluster																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	PTS - Parktronic system																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	AGW - Audio gateway																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	CDC - CD changer																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	AAC - Automatic air conditioning																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	PTC - Electric heater booster																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Engine	CDID2																														V									
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ESM - Electronic selector module																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	ESP - Electronic stability program																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	Suspension																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	EZS - Electronic ignition lock																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	AB - Airbag																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	UCP - Upper control panel																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	SAM - Signal acquisition and actuation module																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FL - Door control module front left																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FR - Door control module front right																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	IC - Instrument cluster																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	PTS - Parktronic system																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	AGW - Audio gateway																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	CDC - CD changer																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																							
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	PTC - Electric heater booster																																							
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Engine	CDI1																																							
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Auto Transaxle	ETC - Electronic transmission control																																							
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	AB - Airbag																																							
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	KR - Wiper																																							
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Information	IC - Instrument cluster																																							
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Air Conditioning	AAC - Automatic air conditioning																																							
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Engine	Engine control unit																																							

Series	Chassis	Type1	Type2	System	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Body	AB - Airbag																																							
Sprinter	Sprinter 2006-Present[W906]	CDI3	Engine	CDI3																																							
Sprinter	Sprinter 2006-Present[W906]	CDI3	Chassis	ESP - Electronic stability program																																							
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	EZS - Electronic ignition lock																																							
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	AB - Airbag																																							
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	UCP - Upper control panel																																							
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	SAM - Signal acquisition and actuation module																																							
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FL - Door control module front left																						V																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FR - Door control module front right																						V																	
Sprinter	Sprinter 2006-Present[W906]	CDI3	Information	IC - Instrument cluster																																							
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	AAC - Automatic air conditioning																																							
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	PTC - Electric heater booster																																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Engine	CDI4																																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ESM - Electronic selector module																																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Chassis	ESP - Electronic stability program																																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	EZS - Electronic ignition lock																																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	AB - Airbag																																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SCM [MRM] - Steering column module																																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	UCP - Upper control panel																																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SAM - Signal acquisition and actuation module																																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Seat/Door	TSG - Door control module front driver side																																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Information	IC - Instrument cluster																																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																							
Sprinter	Sprinter 2006-Present[W906]	CDID	Engine	CDID																													V										
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ETC - Electronic transmission control																																							
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ESM - Electronic selector module																																							
Sprinter	Sprinter 2006-Present[W906]	CDID	Chassis	ESP - Electronic stability program																																							
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	EZS - Electronic ignition lock																																							
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	AB - Airbag																																							
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SCM [MRM] - Steering column module																																							
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	UCP - Upper control panel																																							
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SAM - Signal acquisition and actuation module																																							
Sprinter	Sprinter 2006-Present[W906]	CDID	Seat/Door	TSG - Door control module front driver side																																							
Sprinter	Sprinter 2006-Present[W906]	CDID	Information	IC - Instrument cluster																																							
Sprinter	Sprinter 2006-Present[W906]	CDID	Air Conditioning	AAC - Automatic air conditioning																																							

Series	Chassis	Type1	Type2	System	Correction of elec. suction fan for engine or A/C	Correction programming of fuel quantity	Correction programming of idling specified speed	Correction programming of ignition	Cyclically alternating actuation	Day since last oil change	Days since last oil change	Deactivated system SBC	Default initialization	Denormalization	Denormalization	Denormalization of left front power window	Denormalization of left rear power window	Denormalization of rear-end door closing system	Denormalization of remote trunk closing	Denormalization of right front power window	Denormalization of right rear power window	Denormalization of trunk lid	Denormalize power window	Denormalize Power Windows	Denormalize rear left power window	Denormalize rear right power window	Denormalizing	Denormalizing of left front power window	Denormalizing of left rear power window	Denormalizing of right front power window	Denormalizing of right rear power window	Desensitization of seat belt warning threshold	Distance driven since last oil change	DPF regeneration	EGS/EAG Reset	Electric heater booster adjustment	Electric parking brake	Electric suction fan for engine or A/C	Electrical self-test of microphones	Emergency shift	Emergency tensioning retractor function test	Enabling of engine start after crash event
Sprinter	Sprinter 2006-Present[W906]	CDID2	Engine	CDID2																														V									
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																							
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ESM - Electronic selector module																																							
Sprinter	Sprinter 2006-Present[W906]	CDID2	Chassis	ESP - Electronic stability program																																							
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	EZS - Electronic ignition lock																																							
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	AB - Airbag																																							
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SCM [MRM] - Steering column module																																							
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	UCP - Upper control panel																																							
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SAM - Signal acquisition and actuation module																																							
Sprinter	Sprinter 2006-Present[W906]	CDID2	Seat/Door	TSG - Door control module front driver side																																							
Sprinter	Sprinter 2006-Present[W906]	CDID2	Information	IC - Instrument cluster																																							
Sprinter	Sprinter 2006-Present[W906]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																							
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Engine	CR																																							
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	ETC - Electronic transmission control																																							
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	SSG - Sprint shift transmission																																							
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ABS - Antilock braking system																																							
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ESP - Electronic stability program																																							
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	AB - Airbag																																							
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	ABW - Airbag with window airbag																																							
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	WSP - Immobilizer																																							
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Information	IC - Instrument cluster																																							

Series	Chassis	Type1	Type2	System	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Engine	CDI3																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Engine	CDI4																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	ESP - Electronic stability program							V																															
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	Suspension																												V										
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Engine	CDID																						V																
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	ESP - Electronic stability program							V																															
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	Suspension																												V										
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	AB - Airbag																																						

Series	Chassis	Type1	Type2	System	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Engine	CDID2																					V																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	ESP - Electronic stability program							V																															
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	Suspension																												V										
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Engine	CDI1																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	KR - Wiper																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Air Conditioning	AAC - Automatic air conditioning								V																														
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Engine	Engine control unit																																						

Series	Chassis	Type1	Type2	System	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Engine	CDI3																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FL - Door control module front left																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FR - Door control module front right																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	PTC - Electric heater booster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Engine	CDI4										V																												
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Chassis	ESP - Electronic stability program							V																															
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Engine	CDID																						V																
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Chassis	ESP - Electronic stability program							V																															
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Air Conditioning	AAC - Automatic air conditioning																																						

Series	Chassis	Type1	Type2	System	Enter time with battery disconnected	Erase alarm source	Erase customer-specific data	Erase zero point offset error	Erase zero point offset error of component SAS	Erase zero point offset error of SAS	Exceptional bleeding	Function test	General service	Hot film mass air flow sensor initialization	Information regarding learning processes	Initializing Diesel particulate filter	Injector classification	Injector classification/Injector shutoff	Injector injection quantity adjustment	Injector programming	Injector shutoff test	KEYLESS GO Key search	KEYLESS GO System test	Leakage tests	Learning of fuel pump	Learning of the throttle valve stop	Learning process	Learning process for clutch grip point	Learning process for clutch transmission index	Learning process for gears	Learning process of transfer case	Learning STH Radio remote control transmitter	Level calibration	LF reversible emergency tensioning retractor	Load adjustment	M76/1 (Left electric parking brake actuator motor)	MAXCOOL	Module installation	Move to service position of windshield wiper	Move to the assembly position	National setting	National version factor
Sprinter	Sprinter 2006-Present[W906]	CDID2	Engine	CDID2																						V																
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Chassis	ESP - Electronic stability program							V																															
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Engine	CR													V																									
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	SSG - Sprint shift transmission																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ABS - Antilock braking system																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	AB - Airbag																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	ABW - Airbag with window airbag																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	WSP - Immobilizer																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Information	IC - Instrument cluster																																						

Series	Chassis	Type1	Type2	System	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Engine	CDI3																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FL - Door control module front left													V																									
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FR - Door control module front right													V																									
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Information	IC - Instrument cluster																										V												
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	AAC - Automatic air conditioning													V																									
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Engine	CDI4																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	IC - Instrument cluster																					V																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	AAC - Automatic air conditioning																				V																		
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Engine	CDID																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	AB - Airbag																																						

Series	Chassis	Type1	Type2	System	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	IC - Instrument cluster																					V																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	AAC - Automatic air conditioning																				V																		
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Engine	CDID2																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	IC - Instrument cluster																					V																	
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	AAC - Automatic air conditioning																				V																		
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Engine	CDI1																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	KR - Wiper																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Engine	Engine control unit																																						

Series	Chassis	Type1	Type2	System	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Engine	CDI3																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FL - Door control module front left													V																									
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FR - Door control module front right													V																									
Sprinter	Sprinter 2006-Present[W906]	CDI3	Information	IC - Instrument cluster																										V												
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	AAC - Automatic air conditioning													V																									
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	PTC - Electric heater booster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Engine	CDI4																																		V				
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Information	IC - Instrument cluster																					V																	
Sprinter	Sprinter 2006-Present[W906]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Engine	CDID																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Information	IC - Instrument cluster																					V																	
Sprinter	Sprinter 2006-Present[W906]	CDID	Air Conditioning	AAC - Automatic air conditioning																																						

Series	Chassis	Type1	Type2	System	Normalization	Normalization of actuator motors	Normalization of left rear power window	Normalization of power window	Normalization of right rear power window	Normalize : Backrest	Normalize : Forward/back adjustment	Normalize : Head restraint	Normalize : Height	Normalize : Height at front	Normalize : Seat cushion depth	Normalize power windows	Normalizing	Normalizing : Tilting/Sliding roof	Normalizing of backrest adjustment	Normalizing of forward/back adjustment	Normalizing of head restraint adjustment	Normalizing of height adjustment at front	Normalizing of height adjustment at rear	Normalizing of positioning motors	Oil change	Oil minimum warning	Oil quality	Oxidation catalytic converter	Oxygen sensor upstream of catalytic converter	Perform oil change	Perform teach in process sensor rotor adaptation	Performing sensor rotor adaptation	Permanent fault memory	PML speed-sensitive power steering	Pneumatic tests	Positioning motors normalizing	Power window normalizing	Pressure reduction	Pressure regulator valve initialization	Program brake assist	Rain sensor initialization	Rapid teach-in of zero quantity calibration values
Sprinter	Sprinter 2006-Present[W906]	CDID2	Engine	CDID2																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Information	IC - Instrument cluster																					V																	
Sprinter	Sprinter 2006-Present[W906]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Engine	CR																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	SSG - Sprint shift transmission																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ABS - Antilock braking system																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	AB - Airbag																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	ABW - Airbag with window airbag																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	WSP - Immobilizer																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Information	IC - Instrument cluster																																						

Series	Chassis	Type1	Type2	System	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Engine	CDI3																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Engine	CDI4																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	IC - Instrument cluster																			V																			
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Engine	CDID																	V		V																			
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	AB - Airbag																																						

Series	Chassis	Type1	Type2	System	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	IC - Instrument cluster																				V																		
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Engine	CDID2																	V		V																			
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	IC - Instrument cluster																				V																		
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Engine	CDI1																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	KR - Wiper																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Engine	Engine control unit																																						

Series	Chassis	Type1	Type2	System	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Engine	CDI3																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FL - Door control module front left																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FR - Door control module front right																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	PTC - Electric heater booster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Engine	CDI4		V																																				
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SCM [MRM] - Steering column module													V																									
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	UCP - Upper control panel														V																								
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Seat/Door	TSG - Door control module front driver side															V																							
Sprinter	Sprinter 2006-Present[W906]	CDI4	Information	IC - Instrument cluster																				V																		
Sprinter	Sprinter 2006-Present[W906]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Engine	CDID																	V		V																			
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SCM [MRM] - Steering column module													V																									
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	UCP - Upper control panel														V																								
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Seat/Door	TSG - Door control module front driver side															V																							
Sprinter	Sprinter 2006-Present[W906]	CDID	Information	IC - Instrument cluster																				V																		
Sprinter	Sprinter 2006-Present[W906]	CDID	Air Conditioning	AAC - Automatic air conditioning																																						

Series	Chassis	Type1	Type2	System	Recirculated air flap stop learning	Regeneration DPF	Regeneration of DPF when driving	Regeneration of DPF while driving	Regeneration of the DPF while driving	Reinitialization of AdBlue(R) range	Reinitialize ASSYST	Replace component Diesel particulate filter	Replace component DPF	Replace component M16/6 (Throttle valve actuator)	Replace component NOx storage catalytic converter	Replace component Y74 (Pressure control valve)	Replace control module MRM	Replace control module OBF	Replace control module TSG	Replace quantity mean value adaptation data	Reset adaptation data	Reset coding	Reset fill factor of air filter	Reset inadvertently performed oil change	Reset lambda value	Reset mistakenly confirmed overall maintenance	Reset mistakenly remainder reset	Reset odometer to 0 km	Reset of calibrations	Reset of coding	Reset of compressor operating time	Reset of operating hours counter	Reset of reading of frequency counter crash event	Reset of Shift adaptation data	Reset of T/C lockup clutch adaptation data	Reset operating hours counter	Reset production mode	Reset quantity mean value adaptation data	Reset value Offset value for steering wheel angle	Reset values for HFM drift compensation	Reset values of HFM drift compensation	Reset values of quantity mean value adaptation
Sprinter	Sprinter 2006-Present[W906]	CDID2	Engine	CDID2																	V		V																			
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SCM [MRM] - Steering column module													V																									
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	UCP - Upper control panel														V																								
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Seat/Door	TSG - Door control module front driver side															V																							
Sprinter	Sprinter 2006-Present[W906]	CDID2	Information	IC - Instrument cluster																				V																		
Sprinter	Sprinter 2006-Present[W906]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Engine	CR																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	SSG - Sprint shift transmission																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ABS - Antilock braking system																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	AB - Airbag																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	ABW - Airbag with window airbag																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	WSP - Immobilizer																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Information	IC - Instrument cluster																																						

Series	Chassis	Type1	Type2	System	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning	Self-test	Sensor rotor adaptation
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Engine	CDI3																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Engine	CDI4																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ETC - Electronic transmission control											V																											
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Engine	CDID																													V									
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ETC - Electronic transmission control											V																											
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	AB - Airbag																																						

Series	Chassis	Type1	Type2	System	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning	Self-test	Sensor rotor adaptation
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Engine	CDID2																													V									
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ETC - Electronic transmission control											V																											
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Engine	CDI1																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	KR - Wiper																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Engine	Engine control unit																																						

Series	Chassis	Type1	Type2	System	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning	Self-test	Sensor rotor adaptation
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Engine	CDI3																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FL - Door control module front left																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FR - Door control module front right																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	PTC - Electric heater booster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Engine	CDI4																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ETC - Electronic transmission control											V																											
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Engine	CDID																													V									
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ETC - Electronic transmission control											V																											
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Air Conditioning	AAC - Automatic air conditioning																																						

Series	Chassis	Type1	Type2	System	Resetting adaptation value of AdBlue delivery pump	Resetting adaptation values of shift operations	Resetting air filter learn value after replacement	Resetting calculated fill level of AdBlue tank	Resetting circuit 30g relay frequency counter	Resetting counter of Left parking light	Resetting counter of LF lamp unit fan motor 1	Resetting decoupling relay frequency counter	Resetting ECO Start/Stop function counter	Resetting menu setting to default	Resetting of adaptation data	Resetting of adaptation values	Resetting of contamination level of air filter	Resetting of counter of left front lamp unit	Resetting of counter of LF lamp unit fan motor 1	Resetting of counter of RF lamp unit fan motor 1	Resetting of counter of right front lamp unit	Resetting of learned value of camshaft hall sensor	Resetting of learned values of SGR	Resetting of mixture adaptation	Resetting of sensor adaptation	Resetting of variant locking	Resetting service life data of torque converter	Resetting the adaptation values of the NOx sensors	Resetting the center position of the steering	Resetting the cold start adaptation values	Resetting the counter of left xenon headlamp	Resetting the counter of right xenon headlamp	Resetting the lambda values	RF reversible emergency tensioning retractor	Right electric parking brake actuator motor	Road test	SBC(Sensortronic Brake Control) Setting	SCR catalytic converter	Seat belt extender : Block function automatic	Selection range sensor learning	Self-test	Sensor rotor adaptation
Sprinter	Sprinter 2006-Present[W906]	CDID2	Engine	CDID2																													V									
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ETC - Electronic transmission control											V																											
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Engine	CR																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	SSG - Sprint shift transmission																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ABS - Antilock braking system																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	AB - Airbag																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	ABW - Airbag with window airbag																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	WSP - Immobilizer																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Information	IC - Instrument cluster																																						

Series	Chassis	Type1	Type2	System	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Engine	CDI3																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Chassis	ESP - Electronic stability program																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Engine	CDI4																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	ESP - Electronic stability program									V																													
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Engine	CDID																	V			V																		
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	ESP - Electronic stability program									V																													
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	AB - Airbag																																						

Series	Chassis	Type1	Type2	System	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Engine	CDID2																V			V																			
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ESM - Electronic selector module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	ESP - Electronic stability program									V																													
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	Suspension																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	EZS - Electronic ignition lock																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	UCP - Upper control panel																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	SAM - Signal acquisition and actuation module																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FL - Door control module front left																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FR - Door control module front right																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	PTS - Parktronic system																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	AGW - Audio gateway																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	CDC - CD changer																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																						
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	PTC - Electric heater booster																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Engine	CDI1																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Auto Transaxle	ETC - Electronic transmission control																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	AB - Airbag																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	KR - Wiper																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Information	IC - Instrument cluster																																						
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Air Conditioning	AAC - Automatic air conditioning																																						
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Engine	Engine control unit																																						

Series	Chassis	Type1	Type2	System	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Engine	CDI3																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FL - Door control module front left																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FR - Door control module front right																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	AAC - Automatic air conditioning																																						
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	PTC - Electric heater booster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Engine	CDI4																				V												V			V			
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDI4	Air Conditioning	AAC - Automatic air conditioning											V																											
Sprinter	Sprinter 2006-Present[W906]	CDID	Engine	CDID																	V			V																		
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDID	Air Conditioning	AAC - Automatic air conditioning											V																											

Series	Chassis	Type1	Type2	System	Service remainder reset	Service Reset	Service work of last service	Set of short stroke position of left side window	Set of short stroke position of right side window	Set oil minimum warning	Setting of limit position	Standstill test	Steering angle sensor calibration	Switch off incline recog. for dynamometer mode	Teach in actuator motor	Teach in actuator motors	Teach in boost pressure positioner	Teach in component Boost pressure positioner	Teach in component 'Electric parking brake'	Teach in component 'ESP(R) control valves'	Teach in component glow output stage	Teach in component Y94 (Quantity control valve)	Teach in component Yaw rate acceleration sensor	Teach in new DPF	Teach in of actuator motors	Teach in of DPF after replacement of ECU	Teach in of EGR actuator	Teach in of intake port shutoff	Teach in of lift gate control unit	Teach in of liftgate control unit	Teach in of positions for camshafts	Teach in of selection range sensor	Teach in of throttle valve stop	Teach in of trunk lid control unit	Teach in of trunk lid/liftgate control unit	Teach in process after replacement of DPF	Teach in throttle valve	Teach in transmission neutral position sensor	Teach in used diesel particulate filter	Teach in used DPF	Teach in yaw rate sensor for acceleration	Teach in zero quantity calib. values at idle
Sprinter	Sprinter 2006-Present[W906]	CDID2	Engine	CDID2																	V			V																		
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ESM - Electronic selector module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	EZS - Electronic ignition lock																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	AB - Airbag																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SCM [MRM] - Steering column module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	UCP - Upper control panel																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SAM - Signal acquisition and actuation module																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Seat/Door	TSG - Door control module front driver side																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Information	IC - Instrument cluster																																						
Sprinter	Sprinter 2006-Present[W906]	CDID2	Air Conditioning	AAC - Automatic air conditioning											V																											
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Engine	CR																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	ETC - Electronic transmission control																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	SSG - Sprint shift transmission																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ABS - Antilock braking system																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ESP - Electronic stability program																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	AB - Airbag																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	ABW - Airbag with window airbag																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	WSP - Immobilizer																																						
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Information	IC - Instrument cluster																																						

Series	Chassis	Type1	Type2	System	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Engine	CDI3																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Chassis	ESP - Electronic stability program																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	EZS - Electronic ignition lock																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	AB - Airbag																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	UCP - Upper control panel																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Body	SAM - Signal acquisition and actuation module																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FL - Door control module front left																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Seat/Door	DCM-FR - Door control module front right																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Information	IC - Instrument cluster																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	AAC - Automatic air conditioning																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI3	Air Conditioning	PTC - Electric heater booster																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Engine	CDI4																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Auto Transaxle	ESM - Electronic selector module																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	ESP - Electronic stability program																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Chassis	Suspension																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	EZS - Electronic ignition lock																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	AB - Airbag																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	UCP - Upper control panel																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Body	SAM - Signal acquisition and actuation module																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FL - Door control module front left																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Seat/Door	DCM-FR - Door control module front right																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	IC - Instrument cluster																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	PTS - Parktronic system																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	AGW - Audio gateway																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Information	CDC - CD changer																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDI4	Air Conditioning	PTC - Electric heater booster																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Engine	CDID																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ETC - Electronic transmission control																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Auto Transaxle	ESM - Electronic selector module																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	ESP - Electronic stability program																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Chassis	Suspension																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	EZS - Electronic ignition lock																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	AB - Airbag																																					

Series	Chassis	Type1	Type2	System	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	UCP - Upper control panel																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Body	SAM - Signal acquisition and actuation module																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FL - Door control module front left																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Seat/Door	DCM-FR - Door control module front right																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	IC - Instrument cluster																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	PTS - Parktronic system																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	AGW - Audio gateway																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Information	CDC - CD changer																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	AAC - Automatic air conditioning																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID	Air Conditioning	PTC - Electric heater booster																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Engine	CDID2																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Auto Transaxle	ESM - Electronic selector module																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	ESP - Electronic stability program																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Chassis	Suspension																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	EZS - Electronic ignition lock																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	AB - Airbag																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	UCP - Upper control panel																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Body	SAM - Signal acquisition and actuation module																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FL - Door control module front left																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Seat/Door	DCM-FR - Door control module front right																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	IC - Instrument cluster																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	PTS - Parktronic system																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	AGW - Audio gateway																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Information	CDC - CD changer																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	KBE-H/REAR AC - Rear air conditioning																																					
V-CLASS	Vito/Viano 2004-Present[W639]	CDID2	Air Conditioning	PTC - Electric heater booster																																					
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Engine	CDI1																																					
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Auto Transaxle	ETC - Electronic transmission control																																					
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	AB - Airbag																																					
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Body	KR - Wiper																																					
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Information	IC - Instrument cluster																																					
V-CLASS	Vito/Viano 1996-2004[W638]	16P Connector	Air Conditioning	AAC - Automatic air conditioning																																					
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Engine	Engine control unit																																					

Series	Chassis	Type1	Type2	System	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
V-CLASS	Vito/Viano 1996-2004[W638]	38P Connector	Body	AB - Airbag																																					
Sprinter	Sprinter 2006-Present[W906]	CDI3	Engine	CDI3																																					
Sprinter	Sprinter 2006-Present[W906]	CDI3	Chassis	ESP - Electronic stability program																																					
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	EZS - Electronic ignition lock																																					
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	AB - Airbag																																					
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	UCP - Upper control panel																																					
Sprinter	Sprinter 2006-Present[W906]	CDI3	Body	SAM - Signal acquisition and actuation module																																					
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FL - Door control module front left																																					
Sprinter	Sprinter 2006-Present[W906]	CDI3	Seat/Door	DCM-FR - Door control module front right																																					
Sprinter	Sprinter 2006-Present[W906]	CDI3	Information	IC - Instrument cluster																																					
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	AAC - Automatic air conditioning																																					
Sprinter	Sprinter 2006-Present[W906]	CDI3	Air Conditioning	PTC - Electric heater booster																																					
Sprinter	Sprinter 2006-Present[W906]	CDI4	Engine	CDI4																																					
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ETC - Electronic transmission control																																					
Sprinter	Sprinter 2006-Present[W906]	CDI4	Auto Transaxle	ESM - Electronic selector module																																					
Sprinter	Sprinter 2006-Present[W906]	CDI4	Chassis	ESP - Electronic stability program																																					
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	EZS - Electronic ignition lock																																					
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	AB - Airbag																																					
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SCM [MRM] - Steering column module																																					
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	UCP - Upper control panel																																					
Sprinter	Sprinter 2006-Present[W906]	CDI4	Body	SAM - Signal acquisition and actuation module																																					
Sprinter	Sprinter 2006-Present[W906]	CDI4	Seat/Door	TSG - Door control module front driver side																																					
Sprinter	Sprinter 2006-Present[W906]	CDI4	Information	IC - Instrument cluster																																					
Sprinter	Sprinter 2006-Present[W906]	CDI4	Air Conditioning	AAC - Automatic air conditioning																																					
Sprinter	Sprinter 2006-Present[W906]	CDID	Engine	CDID																																					
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ETC - Electronic transmission control																																					
Sprinter	Sprinter 2006-Present[W906]	CDID	Auto Transaxle	ESM - Electronic selector module																																					
Sprinter	Sprinter 2006-Present[W906]	CDID	Chassis	ESP - Electronic stability program																																					
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	EZS - Electronic ignition lock																																					
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	AB - Airbag																																					
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SCM [MRM] - Steering column module																																					
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	UCP - Upper control panel																																					
Sprinter	Sprinter 2006-Present[W906]	CDID	Body	SAM - Signal acquisition and actuation module																																					
Sprinter	Sprinter 2006-Present[W906]	CDID	Seat/Door	TSG - Door control module front driver side																																					
Sprinter	Sprinter 2006-Present[W906]	CDID	Information	IC - Instrument cluster																																					
Sprinter	Sprinter 2006-Present[W906]	CDID	Air Conditioning	AAC - Automatic air conditioning																																					

Series	Chassis	Type1	Type2	System	Teach in zero quantity calib. values while driving	Teach-in after replace of DPF	Teach-in after replace of O2 sens. upstream of KAT	Teach-in after replace of Pressure control valve	Teach-in after replace of Pressure differ. sensor	Teach-in after replace of SCR catalytic converter	Teach-in of actuator motors	Teach-in of values of zero quantity calibration	Teaching in the DPF after replacing the ECU	Test of component 'S9/1 (Brake light switch)'	Test of compression	Test of left heating capacity	Test of right heating capacity	Test Slot for memory card	Test USB interface	Throttle valve stop learning	Tilting/Sliding roof obstruction sensor learning	Tire pressure loss warner	Tire pressure loss warner (Activating)	Tire pressure sensor ID test	Tourist mode	Tourist mode (Symmetrical light distribution)	Transmitter Reset	Undervoltage switchoff threshold	USB interface	Variant coding	Variant coding reset	VIN Programming	Visual leak test	Warning threshold in days	Windshield adaptation of rain sensor	Write ID numbers of tire pressure sensors	Write tire pressure specified values	Y129 (AdBlue(R) metering valve)	Y74 (Pressure regulating valve)	Zero point setting	Zero position adjustment
Sprinter	Sprinter 2006-Present[W906]	CDID2	Engine	CDID2																																					
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ETC - Electronic transmission control																																					
Sprinter	Sprinter 2006-Present[W906]	CDID2	Auto Transaxle	ESM - Electronic selector module																																					
Sprinter	Sprinter 2006-Present[W906]	CDID2	Chassis	ESP - Electronic stability program																																					
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	EZS - Electronic ignition lock																																					
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	AB - Airbag																																					
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SCM [MRM] - Steering column module																																					
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	UCP - Upper control panel																																					
Sprinter	Sprinter 2006-Present[W906]	CDID2	Body	SAM - Signal acquisition and actuation module																																					
Sprinter	Sprinter 2006-Present[W906]	CDID2	Seat/Door	TSG - Door control module front driver side																																					
Sprinter	Sprinter 2006-Present[W906]	CDID2	Information	IC - Instrument cluster																																					
Sprinter	Sprinter 2006-Present[W906]	CDID2	Air Conditioning	AAC - Automatic air conditioning																																					
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Engine	CR																																					
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	ETC - Electronic transmission control																																					
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Auto Transaxle	SSG - Sprint shift transmission																																					
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ABS - Antilock braking system																																					
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Chassis	ESP - Electronic stability program																																					
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	AB - Airbag																																					
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	ABW - Airbag with window airbag																																					
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Body	WSP - Immobilizer																																					
Sprinter	Sprinter 1996-2005[W90X]	14P Connector	Information	IC - Instrument cluster																																					

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
1 Series	F20 / F21 (2011 - present)	Support Function	CBS Reset					V																																											
1 Series	F20 / F21 (2011 - present)	Support Function	Register battery replacement				V		V																																										
1 Series	F20 / F21 (2011 - present)	Drive	DME (Digital Engine Electronics)	V	V	V	V						V	V	V	V	V	V																																	
1 Series	F20 / F21 (2011 - present)	Drive	EGS (Electronic transmission management)	V	V	V	V														V			V																											
1 Series	F20 / F21 (2011 - present)	Drive	GWS (Gear selector switch)	V	V	V	V																																												
1 Series	F20 / F21 (2011 - present)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
1 Series	F20 / F21 (2011 - present)	Chassis	EPS (Electromechanical power steering)	V	V	V	V																																												
1 Series	F20 / F21 (2011 - present)	Chassis	ICM (Integrated Chassis Management)	V	V	V	V																																												
1 Series	F20 / F21 (2011 - present)	Body	ACSM (Crash Safety Module)	V	V	V	V																																												
1 Series	F20 / F21 (2011 - present)	Body	CBX-MEDIA (Combox Multimedia)	V	V	V	V																																												
1 Series	F20 / F21 (2011 - present)	Body	CON (Controller)	V	V	V	V																																												
1 Series	F20 / F21 (2011 - present)	Body	FEM (Front electronic module)	V	V	V	V																																												
1 Series	F20 / F21 (2011 - present)	Body	HU-B	V	V	V	V																																												
1 Series	F20 / F21 (2011 - present)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V																																												
1 Series	F20 / F21 (2011 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
1 Series	F20 / F21 (2011 - present)	Body	REM (Rear electronic module)	V	V	V	V																																												
1 Series	F20 / F21 (2011 - present)	Body	ZGM (Central Gateway Module)	V			V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Support Function	Techinical information							V																																									
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Support Function	CBS Reset					V																																											
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Support Function	Register battery replacement				V		V																																										
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Drive	CAS (Car Access System)	V	V	V	V					V																																							
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Drive	DME (Digital Motor Electronics)	V	V	V	V						V	V	V	V	V	V		V																															
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Drive	EGS (Electronic transmission control)	V	V	V	V														V	V	V																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Drive	EKPS (Electric fuel pump)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Chassis	AL (Active steering)	V	V		V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Chassis	EPS (Electronic Power Steering)	V	V		V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Chassis	RDC (Tyre pressure control)	V			V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	AMP (Amplifier)	V			V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	CCC-ANT (Aerial tuner)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	CCC-ASK (Audio System controller)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	RAD2 (BMW professional radio)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	RAD2-GW (Gateway)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	M-ASK-BO (User interface)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	M-ASK-GW (Gateway)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	M-ASK-NAV (Navigation system)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	CDC (CD Changer)	V		V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	DAB (Digital tuner)	V			V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	Telephone	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	ULF-SBX-H (Interface box High)	V			V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	CID (Central Information Display)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	CON (Controller)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	CA (Comfort access system)	V			V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	DWA (Anti-theft alarm system)	V			V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	FRM (Footwell module)	V	V	V	V																																	V											
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	FZD (Function centre, roof)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	IHKA (Automatic heating/air conditioning)	V	V	V	V																																V												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	JBE (Junction Box electronics)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	MRS (Multiple restraint system)	V	V		V																														V														
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	PDC (Park Distance Control)	V	V	V	V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	RLS (Rain/driving-lights sensor)	V	V		V																																					V		V					
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	SINE (Siren and tilt sensor)	V			V																																												
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	SMFA (Seat module, driver)	V	V	V	V																																			V										
1 Series	E81 / E82 / E87 / E88 (2004 - 2010)	Body	SMBF (Seat module, passenger)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Support Function	CBS Reset					V																																											
3 Series	F30 / F31 (2012 - present)	Support Function	Register battery replacement				V		V																																										
3 Series	F30 / F31 (2012 - present)	Drive	DME (Digital Engine Electronics)	V	V	V	V						V	V	V	V	V	V																																	
3 Series	F30 / F31 (2012 - present)	Drive	EGS (Electronic transmission management)	V	V	V	V														V			V																											
3 Series	F30 / F31 (2012 - present)	Drive	EKPS (Electronic fuel-pump control)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Drive	GWS (Gear selector switch)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Chassis	EPS (Electromechanical power steering)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Chassis	ICM (Integrated Chassis Management)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	ACSM (Crash Safety Module)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	CBX-MEDIA (Combox Multimedia)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	CIC (Car Information Computer)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	HU-B	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	HU-H	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	CON (Controller)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	FEM (Front electronic module)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	FZD (Function center, roof)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	KAFAS (Camera-based driver-assistance systems)	V	V	V	V																																				V								

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
3 Series	F30 / F31 (2012 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	REM (Rear electronic module)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	REMALI (Reversible electromotive automatic reel - left)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	REMARE (Reversible eletromotive automatic reel - right)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	SMFA (Seat module, driver)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	TBX (Touchbox)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	TRSVC (ALL round-view camera)	V	V	V	V																																												
3 Series	F30 / F31 (2012 - present)	Body	ZGM (Central Gateway Module)	V			V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Support Function	Techinical information							V																																									
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Support Function	CBS Reset					V																																											
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Support Function	Register battery replacement						V																																										
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Drive	CAS (Car Access System)	V	V	V	V					V																																							
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Drive	DME (Digital Motor Electronics)	V	V	V	V						V	V	V	V	V	V		V																															
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Drive	EGS (Electronic transmission control)	V	V	V	V														V	V		V																											
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Drive	EKPS (Electric fuel pump)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Chassis	ACC (Active Cruise Control)	V			V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Chassis	AL (Active steering)	V	V		V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Chassis	EDC (Electronic Damper Control)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Chassis	EPS (Electronic Power Steering)	V			V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Chassis	RDC (Tyre pressure control)	V			V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	AMP (Amplifier)	V			V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	CCC-ANT (Aerial tuner)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	CCC-ASK (Audio System controller)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	CCC-BO (User interface)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	CCC-GW (Gateway)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	CIC (Car Information Computer)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	CIC-GW (Gateway)	V		V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	RAD2 (BMW professional radio)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	RAD2-GW (Gateway)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	M-ASK-BO (User interface)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	M-ASK-GW (Gateway)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	M-ASK-NAV (Navigation system)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	JNAV (Japan navigation system)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	KNAV (Korea navigation system)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	CDC (CD Changer)	V		V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	DAB (Digital tuner)	V			V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	SDARS (Satellite tuner)	V			V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	Telephone	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	ULF (Universal charger and hands-free unit)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	ULF-SBX (Interface box)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	ULF-SBX-H (Interface box High)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	VM (Video module)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	CID (Central Information Display)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	CON (Controller)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	AHM (Trailer Module)	V			V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	CA (Comfort access system)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	CTM (Convertible top module)	V			V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	DWA (Anti-theft alarm system)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	FLA (High Beam Assist)	V		V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	FRM (Footwell module)	V	V	V	V																																	V											
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	FLA (High Beam Assist)	V			V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	FZD (Function centre, roof)	V	V	V	V																																					V							
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	IHKA (Integrated automatic heating/air conditioning)	V	V	V	V																																V												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	JBE (Junction Box electronics)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	MRS (Multiple restraint system)	V	V		V																															V													
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	PDC (Park Distance Control)	V	V	V	V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	RLS (Rain/driving-lights sensor)	V	V		V																																						V		V				
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	SHD (Sliding/tilting sunroof)	V	V	V	V																																					V		V				
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	SINE (Siren and tilt sensor)	V	V		V																																												
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	SMFA (Seat module, driver)	V	V	V	V																																			V									
3 Series	E90 / E91 / E92 / E93 (2006 - 2011)	Body	SMBF (Seat module, passenger)	V	V	V	V																																												
3 Series	E46 (1999 - 2005)	Support Function	Service reset(oil/time/distance)	V	V	V	V	V																																											
3 Series	E46 (1999 - 2005)	Support Function	Clear adaptation(Engine)	V	V	V	V														V																														
3 Series	E46 (1999 - 2005)	Support Function	Clear adaptation(Transmission)	V	V	V	V														V																														
3 Series	E46 (1999 - 2005)	Drive	DME(Engine)	V	V	V	V										V																V	V	V		V													
3 Series	E46 (1999 - 2005)	Drive	EGS(Electronic transmission control)	V	V	V	V														V																														
3 Series	E46 (1999 - 2005)	Drive	EWS (Electronic immobilizer)	V	V		V																																												
3 Series	E46 (1999 - 2005)	Chassis	ABS(Anti-lock Brake System)	V	V	V	V																																												
3 Series	E46 (1999 - 2005)	Chassis	LWS (Steering angle sensor)	V	V		V																																												
3 Series	E46 (1999 - 2005)	Chassis	RDC (Tyre pressure control)	V	V		V																																												
3 Series	E46 (1999 - 2005)	Body	AIC(Automatic Interval Control)	V	V		V																																												
3 Series	E46 (1999 - 2005)	Body	BIT(Basis Interface Telephone)	V	V	V	V																																												V

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
3 Series	E46 (1999 - 2005)	Body	BM(On-board monitor)	V			V																																												
3 Series	E46 (1999 - 2005)	Body	CVM (Convertible-top module)	V	V		V																																												
3 Series	E46 (1999 - 2005)	Body	GM (Basic module)	V	V	V	V																																												
3 Series	E46 (1999 - 2005)	Body	IHKA (Automatic heating/air conditioning)	V	V	V	V																																												
3 Series	E46 (1999 - 2005)	Body	KOMBI (Instrument cluster)	V	V	V	V	V																																											
3 Series	E46 (1999 - 2005)	Body	LSZ/LCM(Light switching center)	V	V	V	V																																												
3 Series	E46 (1999 - 2005)	Body	NAV (Navigation system)	V	V		V																																												
3 Series	E46 (1999 - 2005)	Body	PDC (Park Distance Control)	V	V	V	V																																												
3 Series	E46 (1999 - 2005)	Body	RAD (Radio)	V	V	V	V																																												
3 Series	E46 (1999 - 2005)	Body	SES(Language-input system)	V			V																																												
3 Series	E46 (1999 - 2005)	Body	SHD (Sliding/tilting sunroof)	V	V	V	V																																												
3 Series	E46 (1999 - 2005)	Body	SMB(Entrance aid-passenger)	V	V		V																																												
3 Series	E46 (1999 - 2005)	Body	SMF (Seat memory, driver)	V	V	V	V																																												
3 Series	E46 (1999 - 2005)	Body	SPMBT(Mirror memory-passenger)	V	V	V	V																																												
3 Series	E46 (1999 - 2005)	Body	SPMFT(Mirror memory-drive)	V	V	V	V																																												
3 Series	E46 (1999 - 2005)	Body	MRS/SRS(Airbag)	V	V		V																																												
3 Series	E46 (1999 - 2005)	Body	SZM(Switching center-center console)	V	V	V	V																																												
3 Series	E46 (1999 - 2005)	Body	VM (Video module)	V		V	V																																												
3 Series	E36 (1992 - 1999)	Special function	Service reset(oil/time/distance)	V	V	V	V	V																																											
3 Series	E36 (1992 - 1999)	Special function	Clear adaptation(Engine)	V	V	V	V	V																																											
3 Series	E36 (1992 - 1999)	Special function	Clear adaptation(Transmission)	V	V	V	V	V																																											
3 Series	E36 (1992 - 1999)	Drive	DME(Digital Motor Electronics)	V	V	V	V																																												
3 Series	E36 (1992 - 1999)	Drive	EGS(Electronic transmission control)	V	V	V	V																																												
3 Series	E36 (1992 - 1999)	Drive	EWS(Electronic immobilizer)	V	V		V																																												
3 Series	E36 (1992 - 1999)	Chassis	ABS(Anti-lock braking system)	V	V	V	V																																												
3 Series	E36 (1992 - 1999)	Chassis	LWS (Steering angle sensor)	V	V		V																																												
3 Series	E36 (1992 - 1999)	Body	AB(Airbag)	V	V		V																																												
3 Series	E36 (1992 - 1999)	Body	DWA(Burglar alarm system)	V	V		V																																												
3 Series	E36 (1992 - 1999)	Body	GR2(Cruise control)	V	V	V	V																																												
3 Series	E36 (1992 - 1999)	Body	IHK(Heating and air conditioning)	V	V		V																																												
3 Series	E36 (1992 - 1999)	Body	IRIS(Radio/IR system)	V			V																																												
3 Series	E36 (1992 - 1999)	Body	KOM(Instrument cluster)	V	V	V	V																																												
3 Series	E36 (1992 - 1999)	Body	OBC(On board computer)	V	V		V																																												
3 Series	E36 (1992 - 1999)	Body	PDC (Park Distance Control)	V	V		V																																												
3 Series	E36 (1992 - 1999)	Body	URS(Rollover sensor)	V	V	V	V																																												
3 Series	E36 (1992 - 1999)	Body	GM (Basic module)	V		V	V																																												
3 Series	E30 (1984 - 1991)	1.6 M40 Motronic 1.3	DME	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
3 Series	E30 (1984 - 1991)	1.6 M40 Motronic 1.3	ABS(Anti-lock Brake System)	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	1.6 M40 Motronic 1.3	SRS(Airbag)	V	V		V																																												
3 Series	E30 (1984 - 1991)	1.8 M40 Motronic 1.3	DME	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	1.8 M40 Motronic 1.3	ABS(Anti-lock Brake System)	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	1.8 M40 Motronic 1.3	SRS(Airbag)	V	V		V																																												
3 Series	E30 (1984 - 1991)	1.8 M42 Motronic 1.7	DME	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	1.8 M42 Motronic 1.7	ABS(Anti-lock Brake System)	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	1.8 M42 Motronic 1.7	SRS(Airbag)	V	V		V																																												
3 Series	E30 (1984 - 1991)	2.0 M20 Motronic 1.1	DME	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	2.0 M20 Motronic 1.1	ABS(Anti-lock Brake System)	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	2.0 M20 Motronic 1.1	SRS(Airbag)	V	V		V																																												
3 Series	E30 (1984 - 1991)	2.0 M20 Motronic 1.3	DME	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	2.0 M20 Motronic 1.3	ABS(Anti-lock Brake System)	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	2.0 M20 Motronic 1.3	SRS(Airbag)	V	V		V																																												
3 Series	E30 (1984 - 1991)	2.5 M20 Motronic 1.1	DME	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	2.5 M20 Motronic 1.1	ABS(Anti-lock Brake System)	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	2.5 M20 Motronic 1.1	SRS(Airbag)	V	V		V																																												
3 Series	E30 (1984 - 1991)	2.5 M20 Motronic 1.3	DME	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	2.5 M20 Motronic 1.3	ABS(Anti-lock Brake System)	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	2.5 M20 Motronic 1.3	SRS(Airbag)	V	V		V																																												
3 Series	E30 (1984 - 1991)	2.7 M20 Motronic 1.1	DME	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	2.7 M20 Motronic 1.1	ABS(Anti-lock Brake System)	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	2.7 M20 Motronic 1.1	SRS(Airbag)	V	V		V																																												
3 Series	E30 (1984 - 1991)	2.7 M20 Motronic 1.3	DME	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	2.7 M20 Motronic 1.3	ABS(Anti-lock Brake System)	V	V	V	V																																												
3 Series	E30 (1984 - 1991)	2.7 M20 Motronic 1.3	SRS(Airbag)	V	V		V																																												
4 Series	F32 / F33 (2013 - present)	Support Function	CBS Reset					V																																											
4 Series	F32 / F33 (2013 - present)	Support Function	Register battery replacement				V		V																																										
4 Series	F32 / F33 (2013 - present)	Drive	DME (Digital Engine Electronics)	V	V	V	V						V	V	V	V	V	V																																	
4 Series	F32 / F33 (2013 - present)	Drive	EGS (Electronic transmission management)	V	V	V	V														V			V																											
4 Series	F32 / F33 (2013 - present)	Drive	EKPS (Electronic fuel-pump control)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Drive	GWS (Gear selector switch)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Chassis	EPS (Electromechanical power steering)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Chassis	ICM (Integrated Chassis Management)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	ACSM (Crash Safety Module)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	AMPT (Top Hi-Fi amplifier)	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
4 Series	F32 / F33 (2013 - present)	Body	HU-H	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	CON (Controller)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	CTM (Convertible-top module)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	FEM (Front electronic module)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	FZD (Function center, roof)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	KAFAS (Camera-based driver-assistance systems)	V	V	V	V																																					V							
4 Series	F32 / F33 (2013 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	REM (Rear electronic module)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	REMALI (Reversible electromotive automatic reel - left)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	REMARE (Reversible eletromotive automatic reel - right)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	SINE (Anti-theft alarm system)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	SMFA (Seat module - driver)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	SMBF (Seat module - passenger)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	STML (Headlight driver module, left)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	STMR (Headlight driver module, right)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	SWW (Lane change warning)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	TBX (Touchbox)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	TCB (Telematic Communication Box)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	TRSVC (ALL round-view camera)	V	V	V	V																																												
4 Series	F32 / F33 (2013 - present)	Body	ZGM (Central Gateway Module)	V			V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Support Function	CBS Reset					V																																											
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Support Function	Register battery replacement				V		V																																										
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Drive	CAS (Car Access System)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Drive	DME (Digital Engine Electronics)	V	V	V	V						V	V	V	V	V	V																																	
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Drive	DME2 (Digital Engine Electronics)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Drive	EGS (Electronic transmission management)	V	V	V	V														V			V																											
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Drive	EKPS (Electronic fuel-pump control)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Drive	GWS (Gear selector switch)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Drive	SCR (Selective Catalytic Reduction)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Drive	SVT (Servotronic)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Drive	VTG (Transfer box)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Chassis	EDCSVL (Damper satellite, front left)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Chassis	EDCSVR (Damper satellite, front right)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Chassis	EDCSHL (Damper satellite, rear left)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Chassis	EDCSHR (Damper satellite, rear right)	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Chassis	EMF (Parking brake)	V	V	V	V																													V	V														
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Chassis	EPS (Electromechanical power steering)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Chassis	ICM (Integrated Chassis Management)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Chassis	RDC (Tyre Pressure Monitor)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Chassis	VDM (Vertical Dynamics Management)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	ACSM (Crash Safety Module)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	AHM (Trailer module)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	AMPT (Top Hi-Fi amplifier)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	ASD (Active Sound Design)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	CBX-ECALL (Combox emergency call)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	CBX-MEDIA (Combox Multimedia)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	CHAMP (Central head unit and multimedia platform)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	CIC (Car Information Computer)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	HU-H	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	CID (Central Information Display)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	CON (Controller)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	FRM (Footwell module)	V	V	V	V																																	V	V										
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	HKL (Rear-lid lift)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	FZD (Function center, roof)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	HUD (Head-Up Display)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	JBE (Junction-box electronics)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	KAFAS (Camera-based driver-assistance systems)	V	V	V	V																																				V								
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	PDC (Park Distance Control)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	REMALI (Reversible electromotive automatic reel, left)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	REMARE (Reversible electromotive automatic reel, right)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	RSE (Rear seat entertainment system)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	SMFA (Seat module, driver)	V	V	V	V																																			V									
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	SMBF (Seat module, passenger)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	STML (Headlight driver module, left)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	STMR (Headlight driver module, right)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	LHML (LED main light module, left)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	LHMR (LED main light module, right)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	SWW (Lane change warning)	V	V	V	V																																												
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	SZL (Switch center/ steering column)	V	V	V	V																								V																					
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	TBX (Touchbox)	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	TCB (Telematic Communication Box)	V	V	V	V																																													
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	TRSVC (ALL round-view camera)	V	V	V	V																																													
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	VM (Video module)	V	V	V	V																																													
5 Series	F07 / F10 / F11 / F18 (2010 - present)	Body	ZGM (Central Gateway Module)	V			V																																													
5 Series	E60 / E61 (2004 - 2009)	Support Function	Techinical information							V																																										
5 Series	E60 / E61 (2004 - 2009)	Support Function	CBS Reset					V																																												
5 Series	E60 / E61 (2004 - 2009)	Support Function	Register battery replacement						V																																											
5 Series	E60 / E61 (2004 - 2009)	Drive	CAS (Car Access System)	V	V	V	V					V																																								
5 Series	E60 / E61 (2004 - 2009)	Drive	DME (Digital Motor Electronics)	V	V	V	V						V	V	V	V	V	V		V																																
5 Series	E60 / E61 (2004 - 2009)	Drive	EGS (Electronic transmission control)	V	V	V	V														V	V		V																												
5 Series	E60 / E61 (2004 - 2009)	Drive	EKPS (Electric fuel pump)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Chassis	ACC (Active Cruise Control)	V			V																																													
5 Series	E60 / E61 (2004 - 2009)	Chassis	AL (Active steering)	V	V		V																																													
5 Series	E60 / E61 (2004 - 2009)	Chassis	ARS (Dynamic Drive)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Chassis	RDC (Tyre pressure control)	V			V																																													
5 Series	E60 / E61 (2004 - 2009)	Chassis	EDC (Electronic Damper Control)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Chassis	EHC (Single-axle air suspension)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	AMP (Amplifier)	V			V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	CCC-ANT (Aerial tuner)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	CCC-ASK (Audio System controller)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	CCC-BO (User interface)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	CCC-GW (Gateway)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	M-ASK-BO (User interface)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	M-ASK-GW (Gateway)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	CDC (CD Changer)	V		V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	DVDC (DVD Changer)	V																																																
5 Series	E60 / E61 (2004 - 2009)	Body	DAB (Digital tuner)	V			V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	JNAV (Japn navigation system)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	Telephone	V			V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	VM (Video module)	V			V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	ULF-SBX-H (Interface box High)	V			V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	CID (Central Information Display)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	CON (Controller)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	FD (Rear-compartment display)	V			V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	HUD (Head-Up Display)	V	V	V	V																																													
5 Series	E60 / E61 (2004 - 2009)	Body	KOMBI (Instrument cluster)	V	V	V	V																																													

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
5 Series	E60 / E61 (2004 - 2009)	Body	CA (Comfort access system)	V	V	V	V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	DWA (Anti-theft alarm system)	V	V	V	V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	HKL (Rear-lid lift)	V			V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	KBM (Basic body module)	V	V	V	V																																	V											
5 Series	E60 / E61 (2004 - 2009)	Body	SHD (Sliding/tilting sunroof)	V	V	V	V																																					V		V				
5 Series	E60 / E61 (2004 - 2009)	Body	SINE (Siren and tilt sensor)	V	V		V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	TMFA (Door module, driver)	V	V	V	V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	TMBF (Door module, passenger)	V	V	V	V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	ACSM(Crash Safety Module)	V			V																														V														
5 Series	E60 / E61 (2004 - 2009)	Body	AHM (Trailer Module)	V	V	V	V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	FLA (High Beam Assist)	V		V	V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	KGM (Body gateway module)	V	V	V	V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	LM (Light module)	V	V	V	V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	IHKA (Integrated automatic heating/air conditioning)	V	V	V	V																																V												
5 Series	E60 / E61 (2004 - 2009)	Body	MPM (Micro-power module)	V	V	V	V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	PDC (Park Distance Control)	V	V	V	V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	RLS (Rain/driving-lights sensor)	V	V		V																																					V		V				
5 Series	E60 / E61 (2004 - 2009)	Body	SGM-ZGM (Safety and gateway module)	V			V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	SGM-SIM (Safety and information module)	V	V	V	V																														V														
5 Series	E60 / E61 (2004 - 2009)	Body	SFZ (Satellite vehicle centre)	V	V		V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	SBSL (Satellite, B-pillar, left)	V	V		V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	SBSR (Satellite, B-pillar, right)	V	V		V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	SMFA (Seat module, driver)	V	V	V	V																																			V									
5 Series	E60 / E61 (2004 - 2009)	Body	SMBF (Seat module, passenger)	V	V	V	V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	SZL (Switch centre, steering column)	V			V																																												
5 Series	E60 / E61 (2004 - 2009)	Body	SZM (Centre console control panel)	V	V	V	V																																												
5 Series	E39 (1995 - 2003)	Support Function	Service reset(oil/time/distance)	V	V	V	V	V																																											
5 Series	E39 (1995 - 2003)	Support Function	Clear adaptation(Engine)	V	V	V	V														V																														
5 Series	E39 (1995 - 2003)	Support Function	Clear adaptation(Transmission)	V	V	V	V														V																														
5 Series	E39 (1995 - 2003)	Drive	DME(Engine)	V	V	V	V														V																														
5 Series	E39 (1995 - 2003)	Drive	EGS(Electronic transmission control)	V	V	V	V														V																														
5 Series	E39 (1995 - 2003)	Drive	EWS (Electronic immobilizer)	V	V		V																																												
5 Series	E39 (1995 - 2003)	Drive	GR(Cruise control)	V	V		V																																												
5 Series	E39 (1995 - 2003)	Chassis	ABS/DSC(Anti-lock Brake System)	V	V	V	V																				V																								
5 Series	E39 (1995 - 2003)	Chassis	EHC-EDC(Signal-axle air suspension)	V	V		V																																												
5 Series	E39 (1995 - 2003)	Chassis	LWS (Steering angle sensor)	V	V		V																																												
5 Series	E39 (1995 - 2003)	Body	MRS/SRS(Airbag)	V	V		V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
5 Series	E39 (1995 - 2003)	Body	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
5 Series	E39 (1995 - 2003)	Body	GM (Basic module)	V	V	V	V																																												
5 Series	E39 (1995 - 2003)	Body	LSZ/LCM(Light switching center)	V	V	V	V																																												
5 Series	E39 (1995 - 2003)	Body	SZM(Switching center-center console)	V	V	V	V																																												
5 Series	E39 (1995 - 2003)	Body	PDC (Park Distance Control)	V	V	V	V																																												
5 Series	E39 (1995 - 2003)	Body	AIC(Automatic Interval Control)	V	V		V																																												
5 Series	E39 (1995 - 2003)	Body	MFL(Multi-function steering center)	V	V		V																																												
5 Series	E39 (1995 - 2003)	Body	SHD (Sliding/tilting sunroof)	V			V																																												
5 Series	E39 (1995 - 2003)	Body	SMF (Seat memory, driver)	V	V	V	V																																												
5 Series	E39 (1995 - 2003)	Body	RAD (Radio)	V	V	V	V																																												
5 Series	E39 (1995 - 2003)	Body	BIT(Basis Interface Telephone)	V	V	V	V																																												V
5 Series	E39 (1995 - 2003)	Body	BM(On-board monitor)	V			V																																												
5 Series	E39 (1995 - 2003)	Body	NAV (Navigation system)	V	V		V																																												
5 Series	E39 (1995 - 2003)	Body	VM (Video module)	V			V																																												
5 Series	E39 (1995 - 2003)	Body	SES(Language-input system)	V			V																																												
5 Series	E39 (1995 - 2003)	Body	IHKA/IHKR(Heater/Air Conditioning)	V	V	V	V																																												
5 Series	E34 (1988 - 1995)	Drive	DME(Digital Motor Electronics)	V	V	V	V																																												
5 Series	E34 (1988 - 1995)	Drive	EGS(Electronic transmission control)	V	V	V	V																																												
5 Series	E34 (1988 - 1995)	Drive	EWS(Electronic immobilizer)	V	V		V																																												
5 Series	E34 (1988 - 1995)	Drive	GSA(Differential lock AWD)	V			V																																												
5 Series	E34 (1988 - 1995)	Chassis	ABS(Anti-lock braking system)	V	V	V	V																																												
5 Series	E34 (1988 - 1995)	Chassis	EDC (Electronic Damper Control)	V	V		V																																												
5 Series	E34 (1988 - 1995)	Body	AB(Airbag)	V	V		V																																												
5 Series	E34 (1988 - 1995)	Body	DSHD(Double sunroof)	V	V	V	V																																												
5 Series	E34 (1988 - 1995)	Body	DWA(Burglar alarm system)	V			V																																												
5 Series	E34 (1988 - 1995)	Body	GR2(Cruise control)	V	V	V	V																																												
5 Series	E34 (1988 - 1995)	Body	IHK(Heating and air conditioning)	V	V	V	V																																												
5 Series	E34 (1988 - 1995)	Body	IR(Radio/IR system)	V			V																																												
5 Series	E34 (1988 - 1995)	Body	KOM(Instrument cluster)	V	V	V	V																																												
5 Series	E34 (1988 - 1995)	Body	OBC(On board computer)	V	V		V																																												
5 Series	E34 (1988 - 1995)	Body	PDC (Park Distance Control)	V	V		V																																												
5 Series	E34 (1988 - 1995)	Body	SPM/SM(Seat/Mirror memory)	V	V	V	V																																												
5 Series	E28 (1981 - 1987)	2.0 M20 Motronic 1.1	DME	V	V	V	V																																												
5 Series	E28 (1981 - 1987)	2.0 M20 Motronic 1.1	ABS(Anti-lock Brake System)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.0 M20 Motronic 1.1	SRS(Airbag)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.0 M20 Motronic 1.1	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
5 Series	E28 (1981 - 1987)	2.0 M20 Motronic 1.1	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
5 Series	E28 (1981 - 1987)	2.5 M20 Motronic 1.1	DME	V	V	V	V																																												
5 Series	E28 (1981 - 1987)	2.5 M20 Motronic 1.1	ABS(Anti-lock Brake System)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.5 M20 Motronic 1.1	SRS(Airbag)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.5 M20 Motronic 1.1	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
5 Series	E28 (1981 - 1987)	2.5 M20 Motronic 1.1	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.5 M20 Motronic 1.3	DME	V	V	V	V																																												
5 Series	E28 (1981 - 1987)	2.5 M20 Motronic 1.3	ABS(Anti-lock Brake System)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.5 M20 Motronic 1.3	SRS(Airbag)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.5 M20 Motronic 1.3	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
5 Series	E28 (1981 - 1987)	2.5 M20 Motronic 1.3	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.7 M20 Motronic 1.1	DME	V	V	V	V																																												
5 Series	E28 (1981 - 1987)	2.7 M20 Motronic 1.1	ABS(Anti-lock Brake System)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.7 M20 Motronic 1.1	SRS(Airbag)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.7 M20 Motronic 1.1	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
5 Series	E28 (1981 - 1987)	2.7 M20 Motronic 1.1	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.7 M20 Motronic 1.3	DME	V	V	V	V																																												
5 Series	E28 (1981 - 1987)	2.7 M20 Motronic 1.3	ABS(Anti-lock Brake System)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.7 M20 Motronic 1.3	SRS(Airbag)	V	V		V																																												
5 Series	E28 (1981 - 1987)	2.7 M20 Motronic 1.3	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
5 Series	E28 (1981 - 1987)	2.7 M20 Motronic 1.3	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
5 Series	E28 (1981 - 1987)	3.0 M30 Motronic 1.1	DME	V	V	V	V																																												
5 Series	E28 (1981 - 1987)	3.0 M30 Motronic 1.1	ABS(Anti-lock Brake System)	V	V		V																																												
5 Series	E28 (1981 - 1987)	3.0 M30 Motronic 1.1	SRS(Airbag)	V	V		V																																												
5 Series	E28 (1981 - 1987)	3.0 M30 Motronic 1.1	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
5 Series	E28 (1981 - 1987)	3.0 M30 Motronic 1.1	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
5 Series	E28 (1981 - 1987)	3.4 M30 Motronic 1.1	DME	V	V	V	V																																												
5 Series	E28 (1981 - 1987)	3.4 M30 Motronic 1.1	ABS(Anti-lock Brake System)	V	V		V																																												
5 Series	E28 (1981 - 1987)	3.4 M30 Motronic 1.1	SRS(Airbag)	V	V		V																																												
5 Series	E28 (1981 - 1987)	3.4 M30 Motronic 1.1	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
5 Series	E28 (1981 - 1987)	3.4 M30 Motronic 1.1	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
5 Series	E28 (1981 - 1987)	3.4 M30 Motronic 1.3	DME	V	V	V	V																																												
5 Series	E28 (1981 - 1987)	3.4 M30 Motronic 1.3	ABS(Anti-lock Brake System)	V	V		V																																												
5 Series	E28 (1981 - 1987)	3.4 M30 Motronic 1.3	SRS(Airbag)	V	V		V																																												
5 Series	E28 (1981 - 1987)	3.4 M30 Motronic 1.3	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
5 Series	E28 (1981 - 1987)	3.4 M30 Motronic 1.3	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
5 Series	E28 (1981 - 1987)	3.5 M30 Motronic 1.1	DME	V	V	V	V																																												
5 Series	E28 (1981 - 1987)	3.5 M30 Motronic 1.1	ABS(Anti-lock Brake System)	V	V		V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
5 Series	E28 (1981 - 1987)	3.5 M30 Motronic 1.1	SRS(Airbag)	V	V		V																																												
5 Series	E28 (1981 - 1987)	3.5 M30 Motronic 1.1	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
5 Series	E28 (1981 - 1987)	3.5 M30 Motronic 1.1	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Support Function	CBS Reset					V																																											
6 Series	F06 / F12 / F13 (2011 - present)	Support Function	Register battery replacement				V		V																																										
6 Series	F06 / F12 / F13 (2011 - present)	Drive	CAS (Car Access System)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Drive	DME (Digital Engine Electronics)	V	V	V	V						V	V	V	V	V	V																																	
6 Series	F06 / F12 / F13 (2011 - present)	Drive	DME2 (Digital Engine Electronics)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Drive	EGS (Electronic transmission management)	V	V	V	V														V			V																											
6 Series	F06 / F12 / F13 (2011 - present)	Drive	EKPS (Electronic fuel-pump control)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Drive	GWS (Gear selector switch)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Chassis	AL (Active steering)	V	V		V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Chassis	EDCSVL (Damper satellite, front left)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Chassis	EDCSVR (Damper satellite, front right)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Chassis	EDCSHL (Damper satellite, rear left)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Chassis	EDCSHR (Damper satellite, rear right)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Chassis	EMF (Parking brake)	V	V	V	V																												V	V															
6 Series	F06 / F12 / F13 (2011 - present)	Chassis	EPS (Electromechanical power steering)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Chassis	HSR (Rear-axle slip-angle control)	V	V		V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Chassis	ICM (Integrated Chassis Management)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Chassis	RDC (Tyre Pressure Monitor)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Chassis	VDM (Vertical Dynamics Management)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	ACSM (Crash Safety Module)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	AMPT (Top Hi-Fi amplifier)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	CBX-ECALL (Combox emergency call)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	CBX-MEDIA (Combox Multimedia)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	CIC (Car Information Computer)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	HU-H	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	CID (Central Information Display)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	CON (Controller)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	CVM (Convertible-top module)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	FKA (Rear-cabin automatic A/C)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	FRM (Footwell module)	V	V	V	V																																	V	V										
6 Series	F06 / F12 / F13 (2011 - present)	Body	FZD (Function center, roof)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	HUD (Head-Up Display)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
6 Series	F06 / F12 / F13 (2011 - present)	Body	JBE (Junction-box electronics)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	KAFAS (Camera-based driver-assistance systems)	V	V	V	V																																				V							
6 Series	F06 / F12 / F13 (2011 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	PDC (Park Distance Control)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	REMALI (Reversible electromotive automatic reel, left)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	REMARE (Reversible electromotive automatic reel, right)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	SMFA (Seat module, driver)	V	V	V	V																																				V							
6 Series	F06 / F12 / F13 (2011 - present)	Body	SMBF (Seat module, passenger)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	SWW (Lane change warning)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	SZL (Switch center/ steering column)	V	V	V	V																							V																					
6 Series	F06 / F12 / F13 (2011 - present)	Body	TCB (Telematic Communication Box)	V	V	V	V																																												
6 Series	F06 / F12 / F13 (2011 - present)	Body	TRSVC (ALL round-view camera)	V	V	V	V																																					V							
6 Series	F06 / F12 / F13 (2011 - present)	Body	ZGM (Central Gateway Module)	V			V																																												
6 Series	E63 / E64 (2004 - 2010)	Support Function	Techinical information							V																																									
6 Series	E63 / E64 (2004 - 2010)	Support Function	CBS Reset					V																																											
6 Series	E63 / E64 (2004 - 2010)	Support Function	Register battery replacement						V																																										
6 Series	E63 / E64 (2004 - 2010)	Drive	CAS (Car Access System)	V	V	V	V					V																																							
6 Series	E63 / E64 (2004 - 2010)	Drive	DME (Digital Motor Electronics)	V	V	V	V						V	V	V	V	V	V		V																															
6 Series	E63 / E64 (2004 - 2010)	Drive	EGS (Electronic transmission control)	V	V	V	V														V	V	V																												
6 Series	E63 / E64 (2004 - 2010)	Drive	EKPS (Electric fuel pump)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Drive	VTC(Valvetronic)				V																																												
6 Series	E63 / E64 (2004 - 2010)	Drive	VTC2(Valvetronic)				V																																												
6 Series	E63 / E64 (2004 - 2010)	Chassis	AL (Active steering)	V	V		V																																												
6 Series	E63 / E64 (2004 - 2010)	Chassis	ARS (Dynamic Drive)	V	V		V																		V	V																									
6 Series	E63 / E64 (2004 - 2010)	Chassis	DSC(Dynamic stability control)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Chassis	EDC (Electronic Damper Control)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	AMP (Amplifier)	V			V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	CCC-ANT (Aerial tuner)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	CCC-ASK (Audio System controller)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	CCC-BO (User interface)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	CCC-GW (Gateway)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	CDC (CD Changer)	V		V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	DVDC (DVD Changer)	V			V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	JNAV (Japan navigation system)	V			V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	Telephone	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	VM (Video module)	V		V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	AHL (Adaptive Head Light / headlight vertical aim control)	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
6 Series	E63 / E64 (2004 - 2010)	Body	CID (Central Information Display)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	CON (Controller)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	CVM (Soft top module)	V	V		V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	DWA (Anti-theft alarm system)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	KBM (Basic body module)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	KGM (Body gateway module)	V			V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	IHKA (Automatic heating/air conditioning)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	LM (Light module)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	MPM (Micro-power module)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	PDC (Park Distance Control)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	RLS (Rain/driving-lights sensor)	V	V		V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	SGM-ZGM (Safety and gateway module)	V			V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	SGM-SIM (Safety and information module)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	SFZ (Satellite vehicle centre)	V	V		V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	SBSL (Satellite, B-pillar, left)	V	V		V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	SBSR (Satellite, B-pillar, right)	V	V		V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	SZL (Switch centre, steering column)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	SZM (Centre console control panel)	V	V		V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	TMFA (Door module, driver)	V	V	V	V																																												
6 Series	E63 / E64 (2004 - 2010)	Body	TMBF (Door module, passenger)	V	V	V	V																																												
6 Series	E24 (1976 - 1989)	3.4 M30 Motronic 1.1	DME	V	V	V	V																																												
6 Series	E24 (1976 - 1989)	3.4 M30 Motronic 1.1	ABS(Anti-lock Brake System)	V	V		V																																												
6 Series	E24 (1976 - 1989)	3.4 M30 Motronic 1.1	SRS(Airbag)	V	V		V																																												
6 Series	E24 (1976 - 1989)	3.4 M30 Motronic 1.1	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
6 Series	E24 (1976 - 1989)	3.4 M30 Motronic 1.1	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
6 Series	E24 (1976 - 1989)	3.4 M30 Motronic 1.3	DME	V	V	V	V																																												
6 Series	E24 (1976 - 1989)	3.4 M30 Motronic 1.3	ABS(Anti-lock Brake System)	V	V		V																																												
6 Series	E24 (1976 - 1989)	3.4 M30 Motronic 1.3	SRS(Airbag)	V	V		V																																												
6 Series	E24 (1976 - 1989)	3.4 M30 Motronic 1.3	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
6 Series	E24 (1976 - 1989)	3.4 M30 Motronic 1.3	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
6 Series	E24 (1976 - 1989)	3.5 M30 Motronic 1.1	DME	V	V	V	V																																												
6 Series	E24 (1976 - 1989)	3.5 M30 Motronic 1.1	ABS(Anti-lock Brake System)	V	V		V																																												
6 Series	E24 (1976 - 1989)	3.5 M30 Motronic 1.1	SRS(Airbag)	V	V		V																																												
6 Series	E24 (1976 - 1989)	3.5 M30 Motronic 1.1	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
6 Series	E24 (1976 - 1989)	3.5 M30 Motronic 1.1	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
6 Series	E24 (1976 - 1989)	3.5 M30 Motronic 1.3	DME	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
6 Series	E24 (1976 - 1989)	3.5 M30 Motronic 1.3	ABS(Anti-lock Brake System)	V	V		V																																												
6 Series	E24 (1976 - 1989)	3.5 M30 Motronic 1.3	SRS(Airbag)	V	V		V																																												
6 Series	E24 (1976 - 1989)	3.5 M30 Motronic 1.3	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
6 Series	E24 (1976 - 1989)	3.5 M30 Motronic 1.3	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Support Function	CBS Reset					V																																											
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Support Function	Register battery replacement				V		V																																										
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Drive	CAS (Car Access System)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Drive	DME (Digital Engine Electronics)	V	V	V	V						V	V	V	V	V	V																																	
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Drive	EGS (Electronic transmission management)	V	V	V	V														V			V																											
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Drive	EKPS (Electronic fuel-pump control)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Drive	GWS (Gear selector switch)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	ACC (Active cruise control)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	AL (Active steering)	V	V		V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	EDCSVL (Damper satellite, front left)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	EDCSVR (Damper satellite, front right)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	EDCSHL (Damper satellite, rear left)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	EDCSHR (Damper satellite, rear right)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	EHC (Electronic Ride-Height Control)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	EME (Electrical machine electronics)	V	V		V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	EMF (Parking brake)	V	V	V	V																													V	V														
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	EPS (Electromechanical power steering)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	HSR (Rear-axle slip-angle control)	V	V		V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	ICM (Integrated Chassis Management)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	SME (Battery management electronics)	V	V		V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Chassis	VDM (Vertical Dynamics Management)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	ACSM (Crash Safety Module)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	AMPH (Hi-Fi amplifier)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	AMPT (Top Hi-Fi amplifier)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	CBX-MEDIA (Combox Multimedia)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	CIC (Car Information Computer)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	HU-H	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	CID (Central Information Display)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	CON (Controller)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	DVDC (DVD Changer)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	EMALI (Electric-motor reel, left)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	EMARE (Electric-motor reel, right)	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	FCON (Rear compartment controller)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	FD (Rear-compartment display)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	FD2 (Rear-compartment display 2)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	FKA (Rear-cabin automatic A/C)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	FLA (High-beam assistant)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	FRM (Footwell module)	V	V	V	V																																	V	V										
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	FZD (Function center, roof)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	HKL (Rear-lid lift)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	HUD (Head-Up Display)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	JBE (Junction-box electronics)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	KAFAS (Camera-based driver-assistance systems)	V	V	V	V																																				V								
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	PDC (Park Distance Control)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	RSE (Rear Seat Entertainment)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	SMFA (Seat module, driver)	V	V	V	V																																			V									
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	SMBF (Seat module, passenger)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	SMFAH (Seat module, driver, rear)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	SMBFH (Seat module, passenger, rear)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	STML (Headlight driver module - left)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	STMR (Headlight driver module - right)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	LHML (LED main light module - left)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	LHMR (LED main light module - right)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	SZL (Switch center/ steering column)	V	V	V	V																							V																					
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	TRSVC (ALL round-view camera)	V	V	V	V																																				V								
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	ULF-SBX-H (Interface box High)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	VM (Video Module)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	VSW (video switch)	V	V	V	V																																												
7 Series	F01 / F02 / F03 / F04 (2009 - present)	Body	ZGM (Central Gateway Module)	V			V																																												
7 Series	E65 / E66 (2002 - 2008)	Support Function	Techinical information							V																																									
7 Series	E65 / E66 (2002 - 2008)	Support Function	CBS Reset					V																																											
7 Series	E65 / E66 (2002 - 2008)	Support Function	Register battery replacement						V																																										
7 Series	E65 / E66 (2002 - 2008)	Drive	CAS (Car Access System)	V	V	V	V					V																																							
7 Series	E65 / E66 (2002 - 2008)	Drive	DME (Digital Motor Electronics)	V	V	V	V												V																																
7 Series	E65 / E66 (2002 - 2008)	Drive	DME2 (Digital Motor Electronics)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Drive	EGS (Electronic transmission control)	V	V	V	V														V	V																													
7 Series	E65 / E66 (2002 - 2008)	Drive	VTC(Valvetronic)				V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
7 Series	E65 / E66 (2002 - 2008)	Drive	VTC2(Valvetronic)				V																																													
7 Series	E65 / E66 (2002 - 2008)	Chassis	ACC (Active Cruise Control)	V			V																																													
7 Series	E65 / E66 (2002 - 2008)	Chassis	ARS (Dynamic Drive)	V	V		V																																													
7 Series	E65 / E66 (2002 - 2008)	Chassis	CIM (Chassis Integration Module)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Chassis	DSC (Dynamic stability control)	V	V	V	V																							V																						
7 Series	E65 / E66 (2002 - 2008)	Chassis	EDC (Electronic Damper Control)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Chassis	EHC (Single-axle air suspension)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Chassis	EMF (Parking brake)	V	V	V	V																													V															
7 Series	E65 / E66 (2002 - 2008)	Chassis	RDC (Tyre pressure control)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	AMP (Amplifier)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	ANT (Aerial tuner)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	ASK (Audio system controller)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	CD (Control display)	V		V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	CD-GW (Control Display (Gateway))	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	CDC (CD Changer)	V		V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	DAB (Digital tuner)	V			V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	DVDC (DVD Changer)	V		V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	FBI (Flexible Bus Interface)	V		V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	FD (Rear-compartment display)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	KHI (Headest interface)	V			V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	SDARS (Satellite tuner)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	NAV (Navigation system)	V			V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	SEC (Supplementary control unit)	V			V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	SG-FD (Control unit/rear-compartment display)	V		V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	SG-FD-GW (Control unit/rear-compartment display Gateway)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	SVS (Language processing system)	V		V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	Telephone	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	VM (Video module)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	CON (Controller)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	FCON(Rear compartment controller)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	KOMBI (Instrument cluster)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	AHL (Adaptive directional headlights)	V			V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	FLA (High Beam Assist)	V			V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	LM (Lights Module)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	RLS (Rain/driving-lights sensor)	V	V		V																																						V		V				
7 Series	E65 / E66 (2002 - 2008)	Body	BZM (Centre console control panel)	V	V	V	V																																													
7 Series	E65 / E66 (2002 - 2008)	Body	BZMF (Control centre, centre armrest, rear compartment)	V	V	V	V																																													

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
7 Series	E65 / E66 (2002 - 2008)	Body	SMFA (Seat module, driver)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SMBF (Seat module, passenger)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SMFAH (Seat module, driver, rear)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SMBFH (Seat module, passenger, rear)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	IHKA (Integrated automatic heating/air conditioning)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	FKA (Rear heater/air conditioning)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SHZH (Independent/auxiliry heater)	V			V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SGM-ZGM (Safety and Gateway Module)	V			V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SGM-SIM (Safety and Gateway Module)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SFZ (Satellite vehicle centre)	V	V		V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SASL (Satellite, A-pillar, left)	V	V		V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SASR (Satellite, A-pillar, right)	V	V		V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	STVL (Door satellite, front left)	V	V		V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	STVR (Door satellite, front right)	V	V		V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SSFA (Satellite, seat, driver)	V	V		V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SSBF (Satellite, seat, passenger)	V	V		V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SBSL (Satellite, B-pillar, left)	V	V		V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SBSR (Satellite, B-pillar, right)	V	V		V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SSH (Satellite, seat, rear)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	AHM (Trailer Module)	V			V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	DWA (Anti-theft alarm system)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	HKL (Rear-lid lift)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	PDC (Park Distance Control)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	CA (Comfort access system)	V			V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	PM (Power module)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SHD (Sliding/tilting sunroof)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SINE (Siren and tilt sensor)	V	V		V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	SZL (Switch centre, steering column)	V	V	V	V																																												
7 Series	E65 / E66 (2002 - 2008)	Body	TMFA (Door module, driver's door)	V	V	V	V																																	V											
7 Series	E65 / E66 (2002 - 2008)	Body	TMBF (Door module, passenger door)	V	V	V	V																																	V											
7 Series	E65 / E66 (2002 - 2008)	Body	TMFAH (Door module, rear, driver's side)	V	V	V	V																																	V											
7 Series	E65 / E66 (2002 - 2008)	Body	TMBFH (Door module, rear, passenger's side)	V	V	V	V																																	V											
7 Series	E65 / E66 (2002 - 2008)	Body	WIM (Wiper module)	V	V	V	V																																												
7 Series	E38 (1994 - 2001)	Support Function	Service reset(oil/time/distance)	V	V	V	V	V																																											
7 Series	E38 (1994 - 2001)	Support Function	Clear adaptation(Engine)	V	V	V	V														V																														
7 Series	E38 (1994 - 2001)	Support Function	Clear adaptation(Transmission)	V	V	V	V														V																														
7 Series	E38 (1994 - 2001)	Drive	DME(Engine)	V	V	V	V														V																														

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
7 Series	E38 (1994 - 2001)	Drive	EGS(Electronic transmission control)	V	V	V	V														V																															
7 Series	E38 (1994 - 2001)	Drive	EWS (Electronic immobilizer)	V	V		V																																												
7 Series	E38 (1994 - 2001)	Drive	GR(Cruise control)	V	V	V	V																																												
7 Series	E38 (1994 - 2001)	Drive	EML(Elec. Throttle)	V	V																																														
7 Series	E38 (1994 - 2001)	Chassis	ABS/DSC(Anti-lock Brake System)	V	V	V	V																																												
7 Series	E38 (1994 - 2001)	Chassis	EHC-EDC(Signal-axle air suspension)	V	V		V																																												
7 Series	E38 (1994 - 2001)	Chassis	LWS (Steering angle sensor)	V	V		V																																												
7 Series	E38 (1994 - 2001)	Body	MRS/SRS(Airbag)	V	V		V																																												
7 Series	E38 (1994 - 2001)	Body	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
7 Series	E38 (1994 - 2001)	Body	GM (Basic module)	V	V	V	V																																												
7 Series	E38 (1994 - 2001)	Body	LSZ/LCM(Light switching center)	V	V	V	V																																												
7 Series	E38 (1994 - 2001)	Body	SZM(Switching center-center console)	V	V	V	V																																												
7 Series	E38 (1994 - 2001)	Body	PDC (Park Distance Control)	V	V	V	V																																												
7 Series	E38 (1994 - 2001)	Body	AIC(Automatic Interval Control)	V	V		V																																												
7 Series	E38 (1994 - 2001)	Body	MFL(Multi-function steering center)	V	V		V																																												
7 Series	E38 (1994 - 2001)	Body	SHD (Sliding/tilting sunroof)	V			V																																												
7 Series	E38 (1994 - 2001)	Body	SMF (Seat memory, driver)	V	V	V	V																																												
7 Series	E38 (1994 - 2001)	Body	RAD (Radio)	V	V	V																																													
7 Series	E38 (1994 - 2001)	Body	BIT(Basis Interface Telephone)	V	V	V	V																																												V
7 Series	E38 (1994 - 2001)	Body	BM(On-board monitor)	V			V																																												
7 Series	E38 (1994 - 2001)	Body	NAV (Navigation system)	V	V		V																																												
7 Series	E38 (1994 - 2001)	Body	VM (Video module)	V			V																																												
7 Series	E38 (1994 - 2001)	Body	SES(Language-input system)	V			V																																												
7 Series	E38 (1994 - 2001)	Body	IHKA/IHKR(Heater/Air Conditioning)	V	V	V	V																																												
7 Series	E32 (1986 - 1994)	Drive	DME(Digital Motor Electronics)	V	V	V	V														V																														
7 Series	E32 (1986 - 1994)	Drive	EGS(Electronic transmission control)	V	V	V	V														V																														
7 Series	E32 (1986 - 1994)	Drive	EWS(Electronic immobilizer)	V	V		V																																												
7 Series	E32 (1986 - 1994)	Chassis	ABS(Anti-lock braking system)	V	V	V	V																																												
7 Series	E32 (1986 - 1994)	Chassis	EDC (Electronic Damper Control)	V	V		V																																												
7 Series	E32 (1986 - 1994)	Body	AB(Airbag)	V	V		V																																												
7 Series	E32 (1986 - 1994)	Body	DWA(Burglar alarm system)	V			V																																												
7 Series	E32 (1986 - 1994)	Body	EKM(Electronic body module)	V			V																																												
7 Series	E32 (1986 - 1994)	Body	GR2(Cruise control)	V	V	V	V																																												
7 Series	E32 (1986 - 1994)	Body	IHK(Heating and air conditioning)	V	V		V																																												
7 Series	E32 (1986 - 1994)	Body	IR(Radio/IR system)	V			V																																												
7 Series	E32 (1986 - 1994)	Body	KOM(Instrument cluster)	V	V	V	V																																												
7 Series	E32 (1986 - 1994)	Body	OBC(On board computer)	V	V		V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
8 Series	E31 (1989 - 1997)	4.0 M60 Motronic 3.3	DME	V	V	V	V																																												
8 Series	E31 (1989 - 1997)	4.0 M60 Motronic 3.3	EGS(Electronic transmission control)	V	V	V	V														V																														
8 Series	E31 (1989 - 1997)	4.0 M60 Motronic 3.3	ABS(Anti-lock Brake System)	V	V		V																																												
8 Series	E31 (1989 - 1997)	4.0 M60 Motronic 3.3	SRS(Airbag)	V	V		V																																												
8 Series	E31 (1989 - 1997)	4.0 M60 Motronic 3.3	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
8 Series	E31 (1989 - 1997)	4.0 M60 Motronic 3.3	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
8 Series	E31 (1989 - 1997)	4.4 M62 Motronic 5.2	DME	V	V	V	V																																												
8 Series	E31 (1989 - 1997)	4.4 M62 Motronic 5.2	EGS(Electronic transmission control)	V	V	V	V														V																														
8 Series	E31 (1989 - 1997)	4.4 M62 Motronic 5.2	ABS(Anti-lock Brake System)	V	V		V																																												
8 Series	E31 (1989 - 1997)	4.4 M62 Motronic 5.2	SRS(Airbag)	V	V		V																																												
8 Series	E31 (1989 - 1997)	4.4 M62 Motronic 5.2	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
8 Series	E31 (1989 - 1997)	4.4 M62 Motronic 5.2	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
8 Series	E31 (1989 - 1997)	4.4 M62 Motronic 5.2.1	DME	V	V	V	V																																												
8 Series	E31 (1989 - 1997)	4.4 M62 Motronic 5.2.1	EGS(Electronic transmission control)	V	V	V	V														V																														
8 Series	E31 (1989 - 1997)	4.4 M62 Motronic 5.2.1	ABS(Anti-lock Brake System)	V	V		V																																												
8 Series	E31 (1989 - 1997)	4.4 M62 Motronic 5.2.1	SRS(Airbag)	V	V		V																																												
8 Series	E31 (1989 - 1997)	4.4 M62 Motronic 5.2.1	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
8 Series	E31 (1989 - 1997)	4.4 M62 Motronic 5.2.1	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
8 Series	E31 (1989 - 1997)	5.0 M70 Motronic 1.2	DME	V	V	V	V																																												
8 Series	E31 (1989 - 1997)	5.0 M70 Motronic 1.2	EGS(Electronic transmission control)	V	V	V	V														V																														
8 Series	E31 (1989 - 1997)	5.0 M70 Motronic 1.2	ABS(Anti-lock Brake System)	V	V		V																																												
8 Series	E31 (1989 - 1997)	5.0 M70 Motronic 1.2	SRS(Airbag)	V	V		V																																												
8 Series	E31 (1989 - 1997)	5.0 M70 Motronic 1.2	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
8 Series	E31 (1989 - 1997)	5.0 M70 Motronic 1.2	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
8 Series	E31 (1989 - 1997)	5.0 M70 Motronic 1.7	DME	V	V	V	V																																												
8 Series	E31 (1989 - 1997)	5.0 M70 Motronic 1.7	EGS(Electronic transmission control)	V	V	V	V														V																														
8 Series	E31 (1989 - 1997)	5.0 M70 Motronic 1.7	ABS(Anti-lock Brake System)	V	V		V																																												
8 Series	E31 (1989 - 1997)	5.0 M70 Motronic 1.7	SRS(Airbag)	V	V		V																																												
8 Series	E31 (1989 - 1997)	5.0 M70 Motronic 1.7	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
8 Series	E31 (1989 - 1997)	5.0 M70 Motronic 1.7	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
8 Series	E31 (1989 - 1997)	5.4 M73 Motronic 5.2	DME	V	V	V	V																																												
8 Series	E31 (1989 - 1997)	5.4 M73 Motronic 5.2	EGS(Electronic transmission control)	V	V	V	V														V																														
8 Series	E31 (1989 - 1997)	5.4 M73 Motronic 5.2	ABS(Anti-lock Brake System)	V	V		V																																												
8 Series	E31 (1989 - 1997)	5.4 M73 Motronic 5.2	SRS(Airbag)	V	V		V																																												
8 Series	E31 (1989 - 1997)	5.4 M73 Motronic 5.2	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
8 Series	E31 (1989 - 1997)	5.4 M73 Motronic 5.2	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
8 Series	E31 (1989 - 1997)	5.6 S70 Motronic 1.7.1	DME	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
8 Series	E31 (1989 - 1997)	5.6 S70 Motronic 1.7.1	EGS(Electronic transmission control)	V	V	V	V														V																															
8 Series	E31 (1989 - 1997)	5.6 S70 Motronic 1.7.1	ABS(Anti-lock Brake System)	V	V		V																																												
8 Series	E31 (1989 - 1997)	5.6 S70 Motronic 1.7.1	SRS(Airbag)	V	V		V																																												
8 Series	E31 (1989 - 1997)	5.6 S70 Motronic 1.7.1	IKE/IKI/KOMBI(Instrument cluster)	V	V	V	V	V																																											
8 Series	E31 (1989 - 1997)	5.6 S70 Motronic 1.7.1	IHKA/IHKR(Heater/Air Conditioning)	V	V		V																																												
X1	F48 (2016 - present)	Support Function	CBS Reset					V																																											
X1	F48 (2016 - present)	Support Function	Register battery replacement				V		V																																										
X1	F48 (2016 - present)	Drive	DME (Digital Engine Electronics)	V	V	V	V						V	V	V	V	V	V																																	
X1	F48 (2016 - present)	Drive	EGS (Electronic transmission management)	V	V	V	V														V			V																												
X1	F48 (2016 - present)	Drive	LMV (Longitudinal torque distribution)	V	V	V	V																																												
X1	F48 (2016 - present)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
X1	F48 (2016 - present)	Chassis	EPS (Electromechanical power steering)	V	V	V	V																								V																				
X1	F48 (2016 - present)	Body	ACSM (Crash Safety Module)	V	V	V	V																																												
X1	F48 (2016 - present)	Body	BDC (Body Domain Controller)	V	V	V	V																																												
X1	F48 (2016 - present)	Body	HU-B	V	V	V	V																																												
X1	F48 (2016 - present)	Body	CON (Controller)	V	V	V	V																																												
X1	F48 (2016 - present)	Body	FZD (Function center, roof)	V	V	V	V																																												
X1	F48 (2016 - present)	Body	HKL (Automatic luggage compartment lid actuation)	V	V	V	V																																												
X1	F48 (2016 - present)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V																																												
X1	F48 (2016 - present)	Body	KAFAS (Camera-based driver-assistance systems)	V	V	V	V																																					V							
X1	F48 (2016 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
X1	F48 (2016 - present)	Body	PMA (Parking manoeuvring assistant)	V	V	V	V																																												
X1	F48 (2016 - present)	Body	SMFA (Seat module, driver)	V	V	V	V																																			V									
X1	F48 (2016 - present)	Body	TCB (Telematic Communication Box)	V	V	V	V																																												
X1	F48 (2016 - present)	Body	ZGM (Central Gateway Module)	V			V																																												
X1	E84 (2009 - present)	Special function	Technical information							V																																									
X1	E84 (2009 - present)	Special function	CBS Reset					V																																											
X1	E84 (2009 - present)	Special function	Register battery replacement						V																																										
X1	E84 (2009 - present)	Drive	CAS (Car Access System)	V			V																																												
X1	E84 (2009 - present)	Drive	DME/DDE(Digital motor/Diesel electronics)	V			V																																												
X1	E84 (2009 - present)	Drive	EGS(Electronic transmission control)	V			V																																												
X1	E84 (2009 - present)	Drive	EKPS (Electric fuel pump)	V			V																																												
X1	E84 (2009 - present)	Drive	VTG (Transfer box)	V			V																																												
X1	E84 (2009 - present)	Drive	GWS(Gear selector switch)	V			V																																												
X1	E84 (2009 - present)	Chassis	ACC (Active Cruise Control)	V			V																																												
X1	E84 (2009 - present)	Chassis	AL (Active steering)	V			V																																												
X1	E84 (2009 - present)	Chassis	DSC(Dynamic stability control)	V			V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
X1	E84 (2009 - present)	Chassis	EPS (Electronic Power Steering)	V			V																																												
X1	E84 (2009 - present)	Chassis	EDC (Electronic Damper Control)	V			V																																												
X1	E84 (2009 - present)	Chassis	RDC (Tyre pressure control)	V			V																																												
X1	E84 (2009 - present)	Body	AHL (Adaptive directional headlights)	V			V																																												
X1	E84 (2009 - present)	Body	AHM (Trailer Module)	V			V																																												
X1	E84 (2009 - present)	Body	AMP (Amplifier)	V			V																																												
X1	E84 (2009 - present)	Body	CA (Comfort access system)	V			V																																												
X1	E84 (2009 - present)	Body	CCC-A(Applications)	V			V																																												
X1	E84 (2009 - present)	Body	CCC-ANT (Aerial tuner)	V			V																																												
X1	E84 (2009 - present)	Body	CCC-ASK (Audio System controller)	V			V																																												
X1	E84 (2009 - present)	Body	CCC-BO(User interface)	V			V																																												
X1	E84 (2009 - present)	Body	CCC-GW(Gateway)	V			V																																												
X1	E84 (2009 - present)	Body	CDC (CD Changer)	V			V																																												
X1	E84 (2009 - present)	Body	CID (Central Information Display)	V			V																																												
X1	E84 (2009 - present)	Body	CON (Controller)	V			V																																												
X1	E84 (2009 - present)	Body	CTM (Convertible top module)	V			V																																												
X1	E84 (2009 - present)	Body	DAB (Digital tuner)	V			V																																												
X1	E84 (2009 - present)	Body	DWA (Anti-theft alarm system)	V			V																																												
X1	E84 (2009 - present)	Body	FLA (High Beam Assist)	V			V																																												
X1	E84 (2009 - present)	Body	FRM (Footwell module)	V			V																																												
X1	E84 (2009 - present)	Body	FZD (Function centre, roof)	V			V																																												
X1	E84 (2009 - present)	Body	IHKA (Automatic heating/air conditioning)	V			V																																												
X1	E84 (2009 - present)	Body	KOMBI (Instrument cluster)	V			V																																												
X1	E84 (2009 - present)	Body	JBE (Junction Box electronics)	V			V																																												
X1	E84 (2009 - present)	Body	MRS (Multiple restraint system)	V			V																																												
X1	E84 (2009 - present)	Body	NAV (Navigation system)	V			V																																												
X1	E84 (2009 - present)	Body	PDC (Park Distance Control)	V			V																																												
X1	E84 (2009 - present)	Body	RLS (Rain/driving-lights sensor)	V			V																																												
X1	E84 (2009 - present)	Body	SDARS (Satellite tuner)	V			V																																												
X1	E84 (2009 - present)	Body	SHD (Sliding/tilting sunroof)	V			V																																												
X1	E84 (2009 - present)	Body	SINE (Siren and tilt sensor)	V			V																																												
X1	E84 (2009 - present)	Body	SMBF (Seat module, passenger)	V			V																																												
X1	E84 (2009 - present)	Body	SMFA (Seat module, driver)	V			V																																												
X1	E84 (2009 - present)	Body	TCU (Telematics control unit)	V			V																																												
X1	E84 (2009 - present)	Body	ULF-SBX-H (Interface box High)	V			V																																												
X1	E84 (2009 - present)	Body	VM (Video module)	V			V																																												
X3	F25 (2010 - present)	Support Function	CBS Reset					V																																											

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
X3	F25 (2010 - present)	Support Function	Register battery replacement				V		V																																										
X3	F25 (2010 - present)	Drive	CAS (Car Access System)	V	V	V	V																																												
X3	F25 (2010 - present)	Drive	DME (Digital Engine Electronics)	V	V	V	V						V	V	V	V	V	V																																	
X3	F25 (2010 - present)	Drive	EGS (Electronic transmission management)	V	V	V	V														V			V																											
X3	F25 (2010 - present)	Drive	EKPS (Electronic fuel-pump control)	V	V	V	V																																												
X3	F25 (2010 - present)	Drive	GWS (Gear selector switch)	V	V	V	V																																												
X3	F25 (2010 - present)	Drive	VTG (Transfer box)	V	V	V	V																																												
X3	F25 (2010 - present)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
X3	F25 (2010 - present)	Chassis	EMF (Parking brake)	V	V	V	V																													V	V														
X3	F25 (2010 - present)	Chassis	EPS (Electromechanical power steering)	V	V	V	V																																												
X3	F25 (2010 - present)	Chassis	ICM (Integrated Chassis Management)	V	V	V	V																																												
X3	F25 (2010 - present)	Chassis	RDC (Tyre Pressure Monitor)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	ACSM (Crash Safety Module)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	CBX-MEDIA (Combox Multimedia)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	CIC (Car Information Computer)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	HU-H	V	V	V	V																																												
X3	F25 (2010 - present)	Body	CID (Central Information Display)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	CON (Controller)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	FRM (Footwell module)	V	V	V	V																																		V	V									
X3	F25 (2010 - present)	Body	FZD (Function center, roof)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	HKL (Automatic luggage compartment lid actuation)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	HUD (Head-Up Display)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	JBE (Junction-box electronics)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	KAFAS (Camera-based driver-assistance systems)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	PDC (Park Distance Control)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	PMA (Parking manoeuvring assistant)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	SMFA (Seat module, driver)	V	V	V	V																																				V									
X3	F25 (2010 - present)	Body	TBX (Touchbox)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	TCB (Telematic Communication Box)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	TRSVC (ALL round-view camera)	V	V	V	V																																												
X3	F25 (2010 - present)	Body	ZGM (Central Gateway Module)	V			V																																												
X3	E83 (2004 - 2009)	Drive	DME (Motor Electronics)	V	V	V	V						V					V																																	
X3	E83 (2004 - 2009)	Drive	EGS (Electronic transmission management)	V	V	V	V														V	V																													
X3	E83 (2004 - 2009)	Drive	VTG (Transfer box)	V	V	V	V																																												
X3	E83 (2004 - 2009)	Drive	EWS (Electronic immobilizer)	V	V		V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
X3	E83 (2004 - 2009)	Chassis	DSC (Dynamic stability control)	V	V	V	V																								V																				
X3	E83 (2004 - 2009)	Chassis	LWS (Steering angle sensor)	V	V		V																																												
X3	E83 (2004 - 2009)	Chassis	RDC (Tyre pressure control)	V			V																																												
X3	E83 (2004 - 2009)	Body	AHL (Adaptive Head Light / headlight vertical aim control)	V	V	V	V																																												
X3	E83 (2004 - 2009)	Body	CID (Central Information Display)	V			V																																												
X3	E83 (2004 - 2009)	Body	GM (Basic module)	V	V	V	V																																												
X3	E83 (2004 - 2009)	Body	IHKA (Automatic heating/air conditioning)	V	V	V	V																																												
X3	E83 (2004 - 2009)	Body	KOMBI (Instrument cluster)	V	V	V	V	V																																											
X3	E83 (2004 - 2009)	Body	LM (Lights Module)	V	V	V	V																																												
X3	E83 (2004 - 2009)	Body	MFL (Multifunction steering wheel)		V		V																																												
X3	E83 (2004 - 2009)	Body	MRS/SRS(Airbag)	V	V		V																																												
X3	E83 (2004 - 2009)	Body	NAV (Navigation system)	V	V		V																																												
X3	E83 (2004 - 2009)	Body	PDC (Park Distance Control)	V	V	V	V																																												
X3	E83 (2004 - 2009)	Body	RAD (Radio)	V	V	V	V																																												
X3	E83 (2004 - 2009)	Body	RLS (Rain/driving-lights sensor)	V	V		V																																												
X3	E83 (2004 - 2009)	Body	SHD (Sliding/tilting sunroof)	V	V	V	V																																												
X3	E83 (2004 - 2009)	Body	SMF (Seat memory, driver)	V	V	V	V																																												
X3	E83 (2004 - 2009)	Body	SZM (Centre console control panel)	V	V	V	V																																												
X3	E83 (2004 - 2009)	Body	TCU (Telematics control unit)	V	V	V	V																																												
X3	E83 (2004 - 2009)	Body	VM (Video module)	V		V	V																																												
X5	F15 (2013 - present)	Support Function	CBS Reset					V																																											
X5	F15 (2013 - present)	Support Function	Register battery replacement				V		V																																										
X5	F15 (2013 - present)	Drive	DME (Digital Engine Electronics)	V	V	V	V						V	V	V	V	V	V		V																															
X5	F15 (2013 - present)	Drive	DME2 (Digital Engine Electronics)	V	V	V	V																																												
X5	F15 (2013 - present)	Drive	EGS (Electronic transmission management)	V	V	V	V														V			V																											
X5	F15 (2013 - present)	Drive	EKPS (Electronic fuel-pump control)	V	V	V	V																																												
X5	F15 (2013 - present)	Drive	GWS (Gear selector switch)	V	V	V	V																																												
X5	F15 (2013 - present)	Drive	VTG (Transfer box)	V	V	V	V																																												
X5	F15 (2013 - present)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
X5	F15 (2013 - present)	Chassis	EMF (Parking brake)	V	V	V	V																													V	V														
X5	F15 (2013 - present)	Chassis	EPS (Electromechanical power steering)	V	V	V	V																																												
X5	F15 (2013 - present)	Chassis	ICM (Integrated Chassis Management)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	ACSM (Crash Safety Module)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	AMPT (Top Hi-Fi amplifier)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	BDC (Body Domain Controller)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	HU-H	V	V	V	V																																												
X5	F15 (2013 - present)	Body	CID (Central Information Display)	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
X5	F15 (2013 - present)	Body	CON (Controller)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	HKL (Automatic luggage compartment lid actuation)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	KAFAS (Camera-based driver-assistance systems)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	PCU (Power Control Unit)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	PMA (Parking manoeuvring assistant)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	SMFA (Seat module, driver)	V	V	V	V																																				V								
X5	F15 (2013 - present)	Body	SMBF (Seat module, passenger)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	STML (Headlight driver module, left)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	STMR (Headlight driver module, right)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	SWW (Lane change warning)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	TBX (Touchbox)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	TCB (Telematic Communication Box)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	TRSVC (ALL round-view camera)	V	V	V	V																																												
X5	F15 (2013 - present)	Body	ZGM (Central Gateway Module)	V			V																																												
X5	E70 (2007 - present)	Support Function	Technical information							V																																									
X5	E70 (2007 - present)	Support Function	CBS Reset					V																																											
X5	E70 (2007 - present)	Support Function	Register battery replacement						V																																										
X5	E70 (2007 - present)	Drive	CAS (Car Access System)	V	V	V	V					V																																							
X5	E70 (2007 - present)	Drive	DME/DDE(Digital motor/Diesel electronics)	V	V	V	V						V	V	V	V	V	V		V																															
X5	E70 (2007 - present)	Drive	EGS(Electronic transmission control)	V	V	V	V														V	V	V																												
X5	E70 (2007 - present)	Drive	EKPS (Electric fuel pump)	V	V	V	V																																												
X5	E70 (2007 - present)	Drive	GWS(Gear selector switch)	V	V	V	V																																												
X5	E70 (2007 - present)	Drive	QMVH (Lateral-moment distribution, rear axle)	V	V		V																																												
X5	E70 (2007 - present)	Drive	SVT (Servotronic)	V	V		V																																												
X5	E70 (2007 - present)	Drive	VTC (Valvetronic, bank 1)				V																																												
X5	E70 (2007 - present)	Drive	VTC2 (Valvetronic, bank 2)				V																																												
X5	E70 (2007 - present)	Drive	VTG (Transfer box)	V	V	V	V																																												
X5	E70 (2007 - present)	Chassis	AL (Active steering)	V	V		V																								V																				
X5	E70 (2007 - present)	Chassis	ARS (Dynamic Drive)	V	V	V	V																		V	V																									
X5	E70 (2007 - present)	Chassis	DSC(Dynamic stability control)	V	V	V	V																																												
X5	E70 (2007 - present)	Chassis	EDCSVL(Damper satellite/front left)	V	V	V	V																																												
X5	E70 (2007 - present)	Chassis	EDCSVR(Damper satellite/front right)	V	V	V	V																																												
X5	E70 (2007 - present)	Chassis	EDCSHL(Damper satellite/rear left)	V	V	V	V																																												
X5	E70 (2007 - present)	Chassis	EDCSHR(Damper satellite/rear right)	V	V	V	V																																												
X5	E70 (2007 - present)	Chassis	EHC (Single-axle air suspension)	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
X5	E70 (2007 - present)	Chassis	EMF (Parking brake)	V	V		V																													V	V														
X5	E70 (2007 - present)	Chassis	RDC (Tyre pressure control)	V	V	V	V																																												
X5	E70 (2007 - present)	Chassis	VDM(Vertical Dynamics Management)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	AMP (Amplifier)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	CBX-MEDIA (Combox Multimedia)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	CCC-ANT (Aerial tuner)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	CCC-ASK (Audio System controller)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	User interface	V	V	V	V																																												
X5	E70 (2007 - present)	Body	Gateway	V	V	V	V																																												
X5	E70 (2007 - present)	Body	CDC (CD Changer)	V		V	V																																												
X5	E70 (2007 - present)	Body	DVDC (DVD Changer)	V		V	V																																												
X5	E70 (2007 - present)	Body	NAV (Navigation system)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	SDARS (Satellite tuner)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	TCU (Telematics control unit)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	VM (Video module)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	ULF-SBX-H (Interface box High)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	CID (Central Information Display)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	CON (Controller)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	FD (Rear-compartment display)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	HUD (Head-Up Display)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	TRSVC (ALL round-view camera)	V	V	V	V																																				V								
X5	E70 (2007 - present)	Body	ACSM(Crash Safety Module)	V	V		V																																												
X5	E70 (2007 - present)	Body	AHM (Trailer Module)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	CA (Comfort access system)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	FKA (Rear heater/air conditioning)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	FLA (High Beam Assist)	V		V	V																																												
X5	E70 (2007 - present)	Body	FRM (Footwell module)	V	V	V	V																																		V										
X5	E70 (2007 - present)	Body	FZD (Function centre, roof)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	HKL (Rear-lid lift)	V	V	V	V																													V															
X5	E70 (2007 - present)	Body	IHKA (Automatic heating/air conditioning)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	JBE (Junction Box electronics)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	PDC (Park Distance Control)	V	V	V	V																																												
X5	E70 (2007 - present)	Body	RFK (Reversing camera)	V	V	V	V																																				V								
X5	E70 (2007 - present)	Body	RLS (Rain/driving-lights sensor)	V	V		V																																						V						
X5	E70 (2007 - present)	Body	SHZH (Independent/auxiliry heater)	V			V																																												
X5	E70 (2007 - present)	Body	SINE (Siren and tilt sensor)	V	V		V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
X5	E70 (2007 - present)	Body	SMFA (Seat module, driver)	V	V	V	V																																			V								
X5	E53 (2000 - 2006)	Special function	Service interval reset					V																																										
X5	E53 (2000 - 2006)	Special function	Technical information								V																																						V	
X5	E53 (2000 - 2006)	Drive	DME (Motor Electronics)	V	V	V	V						V																																					
X5	E53 (2000 - 2006)	Drive	EGS (Transmission management)	V	V	V	V														V																													
X5	E53 (2000 - 2006)	Drive	EWS (Electronic immobilizer)	V	V		V																																											
X5	E53 (2000 - 2006)	Drive	VTG (Transfer box)	V	V	V	V																																											
X5	E53 (2000 - 2006)	Chassis	DSC (Dynamic stability control)	V	V	V	V																				V	V	V	V																				
X5	E53 (2000 - 2006)	Chassis	EHC (Single-axle air suspension)	V	V		V																																											
X5	E53 (2000 - 2006)	Chassis	LWS (Steering angle sensor)	V	V		V																																											
X5	E53 (2000 - 2006)	Chassis	RDC (Tyre pressure control)	V			V																																											
X5	E53 (2000 - 2006)	Body	AHL (Adaptive Head Light / headlight vertical aim control)	V	V	V	V																																											
X5	E53 (2000 - 2006)	Body	BM (On-board monitor, widescreen)	V			V																																											
X5	E53 (2000 - 2006)	Body	DSP (Digital sound processor)	V	V		V																																											
X5	E53 (2000 - 2006)	Body	CDC (CD Changer)	V		V	V																																											
X5	E53 (2000 - 2006)	Body	GM (Basic module)	V	V	V	V																																											
X5	E53 (2000 - 2006)	Body	IHKA (Automatic heating/air conditioning)	V	V		V																																											
X5	E53 (2000 - 2006)	Body	IKE(Instrument cluster)	V	V	V	V																																											
X5	E53 (2000 - 2006)	Body	LCM(Lamp check module)	V	V	V	V																																											
X5	E53 (2000 - 2006)	Body	LRA (Automatic headlight vertical aim control)	V	V	V	V																																											
X5	E53 (2000 - 2006)	Body	MFL(Multi-function steering wheel)		V		V																																											
X5	E53 (2000 - 2006)	Body	MID (Multi Information Display)	V			V																																											
X5	E53 (2000 - 2006)	Body	MRS (Multiple restraint system)	V	V		V																																											
X5	E53 (2000 - 2006)	Body	NAV (Navigation system)	V	V		V																																											
X5	E53 (2000 - 2006)	Body	PDC (Park Distance Control)	V	V	V	V																																											
X5	E53 (2000 - 2006)	Body	RAD (Radio)	V	V	V	V																																											
X5	E53 (2000 - 2006)	Body	RLS (Rain/driving-lights sensor)	V	V	V	V																																						V		V		V	
X5	E53 (2000 - 2006)	Body	SES(Language input system)	V			V																																											
X5	E53 (2000 - 2006)	Body	SHD (Sliding/tilting sunroof)	V	V		V																																											
X5	E53 (2000 - 2006)	Body	SM/SLM(Seat/Steering column memory)	V	V	V	V																																											
X5	E53 (2000 - 2006)	Body	SZM(Switching center, center console)	V	V	V	V																																											
X5	E53 (2000 - 2006)	Body	TCU (Telematic Control Unit (I bus))	V	V	V	V																																											V
X5	E53 (2000 - 2006)	Body	VM (Video module)	V		V	V																																											
X6	F16 (2014 - present)	Support Function	CBS Reset					V																																										
X6	F16 (2014 - present)	Support Function	Register battery replacement				V		V																																									
X6	F16 (2014 - present)	Drive	DME (Digital Engine Electronics)	V	V	V	V						V	V	V	V	V	V		V																														
X6	F16 (2014 - present)	Drive	DME2 (Digital Engine Electronics)	V	V	V	V																																											

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
X6	F16 (2014 - present)	Drive	EGS (Electronic transmission management)	V	V	V	V														V			V																											
X6	F16 (2014 - present)	Drive	EKPS (Electronic fuel-pump control)	V	V	V	V																																												
X6	F16 (2014 - present)	Drive	GWS (Gear selector switch)	V	V	V	V																																												
X6	F16 (2014 - present)	Drive	VTG (Transfer box)	V	V	V	V																																												
X6	F16 (2014 - present)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
X6	F16 (2014 - present)	Chassis	EMF (Parking brake)	V	V	V	V																													V	V														
X6	F16 (2014 - present)	Chassis	EPS (Electromechanical power steering)	V	V	V	V																																												
X6	F16 (2014 - present)	Chassis	ICM (Integrated Chassis Management)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	ACSM (Crash Safety Module)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	AMPT (Top Hi-Fi amplifier)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	BDC (Body Domain Controller)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	HU-H	V	V	V	V																																												
X6	F16 (2014 - present)	Body	CID (Central Information Display)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	CON (Controller)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	HKL (Automatic luggage compartment lid actuation)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	KAFAS (Camera-based driver-assistance systems)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	PCU (Power Control Unit)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	PMA (Parking manoeuvring assistant)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	SMFA (Seat module, driver)	V	V	V	V																																				V									
X6	F16 (2014 - present)	Body	SMBF (Seat module, passenger)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	STML (Headlight driver module, left)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	STMR (Headlight driver module, right)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	SWW (Lane change warning)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	TBX (Touchbox)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	TCB (Telematic Communication Box)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	TRSVC (ALL round-view camera)	V	V	V	V																																												
X6	F16 (2014 - present)	Body	ZGM (Central Gateway Module)	V			V																																												
X6	E71 (2008 - present)	Support Function	Technical information							V																																									
X6	E71 (2008 - present)	Support Function	CBS Reset					V																																											
X6	E71 (2008 - present)	Support Function	Register battery replacement						V																																										
X6	E71 (2008 - present)	Drive	CAS (Car Access System)	V	V	V	V					V																																							
X6	E71 (2008 - present)	Drive	DME/DDE(Digital motor/Diesel electronics)	V	V	V	V						V	V	V	V	V	V		V																															
X6	E71 (2008 - present)	Drive	EGS(Electronic transmission control)	V	V	V	V														V	V	V																												
X6	E71 (2008 - present)	Drive	EKPS (Electric fuel pump)	V	V	V	V																																												
X6	E71 (2008 - present)	Drive	GWS(Gear selector switch)	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
X6	E71 (2008 - present)	Drive	QMVH (Lateral-moment distribution, rear axle)	V	V		V																																												
X6	E71 (2008 - present)	Drive	SVT (Servotronic)	V	V		V																																												
X6	E71 (2008 - present)	Drive	VTC (Valvetronic, bank 1)				V																																												
X6	E71 (2008 - present)	Drive	VTC2 (Valvetronic, bank 2)				V																																												
X6	E71 (2008 - present)	Drive	VTG (Transfer box)	V	V	V	V																																												
X6	E71 (2008 - present)	Chassis	AL (Active steering)	V	V		V																								V																				
X6	E71 (2008 - present)	Chassis	ARS (Dynamic Drive)	V	V	V	V																		V	V																									
X6	E71 (2008 - present)	Chassis	DSC(Dynamic stability control)	V	V	V	V																																												
X6	E71 (2008 - present)	Chassis	EDCSVL(Damper satellite/front left)	V	V	V	V																																												
X6	E71 (2008 - present)	Chassis	EDCSVR(Damper satellite/front right)	V	V	V	V																																												
X6	E71 (2008 - present)	Chassis	EDCSHL(Damper satellite/rear left)	V	V	V	V																																												
X6	E71 (2008 - present)	Chassis	EDCSHR(Damper satellite/rear right)	V	V	V	V																																												
X6	E71 (2008 - present)	Chassis	EHC (Single-axle air suspension)	V	V	V	V																																												
X6	E71 (2008 - present)	Chassis	EMF (Parking brake)	V	V		V																													V	V														
X6	E71 (2008 - present)	Chassis	RDC (Tyre pressure control)	V	V	V	V																																												
X6	E71 (2008 - present)	Chassis	VDM(Vertical Dynamics Management)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	AMP (Amplifier)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	CBX-MEDIA (Combox Multimedia)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	CCC-ANT (Aerial tuner)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	CCC-ASK (Audio System controller)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	User interface	V	V	V	V																																												
X6	E71 (2008 - present)	Body	Gateway	V	V	V	V																																												
X6	E71 (2008 - present)	Body	CDC (CD Changer)	V		V	V																																												
X6	E71 (2008 - present)	Body	DVDC (DVD Changer)	V		V	V																																												
X6	E71 (2008 - present)	Body	NAV (Navigation system)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	SDARS (Satellite tuner)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	TCU (Telematics control unit)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	VM (Video module)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	ULF-SBX-H (Interface box High)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	CID (Central Information Display)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	CON (Controller)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	FD (Rear-compartment display)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	HUD (Head-Up Display)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	TRSVC (ALL round-view camera)	V	V	V	V																																					V								
X6	E71 (2008 - present)	Body	ACSM(Crash Safety Module)	V	V		V																																												
X6	E71 (2008 - present)	Body	AHM (Trailer Module)	V	V	V	V																																												

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
X6	E71 (2008 - present)	Body	CA (Comfort access system)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	FKA (Rear heater/air conditioning)	V	V	V	V																																												
X6	E71 (2008 - present)	Body	FLA (High Beam Assist)	V		V	V																																												
X6	E71 (2008 - present)	Body	FRM (Footwell module)	V	V	V	V																																V											
X6	E71 (2008 - present)	Body	FZD (Function centre, roof)	V	V	V	V																																											
X6	E71 (2008 - present)	Body	HKL (Rear-lid lift)	V	V	V	V																												V															
X6	E71 (2008 - present)	Body	IHKA (Automatic heating/air conditioning)	V	V	V	V																																											
X6	E71 (2008 - present)	Body	JBE (Junction Box electronics)	V	V	V	V																																											
X6	E71 (2008 - present)	Body	PDC (Park Distance Control)	V	V	V	V																																											
X6	E71 (2008 - present)	Body	RFK (Reversing camera)	V	V	V	V																																				V							
X6	E71 (2008 - present)	Body	RLS (Rain/driving-lights sensor)	V	V		V																																						V					
X6	E71 (2008 - present)	Body	SHZH (Independent/auxiliry heater)	V			V																																											
X6	E71 (2008 - present)	Body	SINE (Siren and tilt sensor)	V	V		V																																											
X6	E71 (2008 - present)	Body	SMFA (Seat module, driver)	V	V	V	V																																											
X6	E71 (2008 - present)	Body	SMBF (Seat module, passenger)	V	V	V	V																																				V							
Z Series	Z4 (E89) (2009 - present)	Support Function	Technical information							V																																								
Z Series	Z4 (E89) (2009 - present)	Support Function	CBS Reset					V																																										
Z Series	Z4 (E89) (2009 - present)	Support Function	Register battery replacement						V																																									
Z Series	Z4 (E89) (2009 - present)	Drive	CAS (Car Access System)	V	V	V	V					V																																						
Z Series	Z4 (E89) (2009 - present)	Drive	DME/DDE(Digital motor/Diesel electronics)	V	V	V	V						V	V	V	V	V	V		V																														
Z Series	Z4 (E89) (2009 - present)	Drive	EGS (Electronic transmission management)	V	V	V	V														V	V	V																											
Z Series	Z4 (E89) (2009 - present)	Drive	EKPS (Electronic fuel-pump control)	V	V	V	V																																											
Z Series	Z4 (E89) (2009 - present)	Chassis	DSC (Dynamic stability control)	V	V	V	V																							V																				
Z Series	Z4 (E89) (2009 - present)	Chassis	EDC (Electronic Damper Control)	V	V	V	V																																											
Z Series	Z4 (E89) (2009 - present)	Chassis	EMF (Parking brake)	V	V	V	V																													V														
Z Series	Z4 (E89) (2009 - present)	Chassis	EPS (Electromechanical power steering)	V	V		V																																											
Z Series	Z4 (E89) (2009 - present)	Body	AMP (Amplifier)	V	V	V	V																																											
Z Series	Z4 (E89) (2009 - present)	Body	ASD (Active Sound Design)	V	V	V	V																																											
Z Series	Z4 (E89) (2009 - present)	Body	CIC (Car Information Computer)	V	V	V	V																															V												
Z Series	Z4 (E89) (2009 - present)	Body	CIC-GW (Gateway)	V	V	V	V																																											
Z Series	Z4 (E89) (2009 - present)	Body	RAD2 (BMW professional radio)	V	V	V	V																																											
Z Series	Z4 (E89) (2009 - present)	Body	RAD2-GW (Gateway)	V	V	V	V																																											
Z Series	Z4 (E89) (2009 - present)	Body	CBX-MEDIA (Combox Multimedia)	V	V	V	V																																											
Z Series	Z4 (E89) (2009 - present)	Body	CID (Central Information Display)	V	V	V	V																																											
Z Series	Z4 (E89) (2009 - present)	Body	CON (Controller)	V	V	V	V																																											
Z Series	Z4 (E89) (2009 - present)	Body	CTM (Convertible top module)	V	V		V																																									V		
Z Series	Z4 (E89) (2009 - present)	Body	DVDC (DVD Changer)	V		V	V																																											

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
Z Series	Z4 (E89) (2009 - present)	Body	FRM (Footwell module)	V	V	V	V																																	V											
Z Series	Z4 (E89) (2009 - present)	Body	FZD (Function centre, roof)	V	V	V	V																																												
Z Series	Z4 (E89) (2009 - present)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V																																V												
Z Series	Z4 (E89) (2009 - present)	Body	JBE (Junction-box electronics)	V	V	V	V																																												
Z Series	Z4 (E89) (2009 - present)	Body	KOMBI (Instrument cluster)	V	V	V	V																																												
Z Series	Z4 (E89) (2009 - present)	Body	MRS (Multiple Restraint System)	V	V		V																														V														
Z Series	Z4 (E89) (2009 - present)	Body	PDC (Park Distance Control)	V	V	V	V																																												
Z Series	Z4 (E89) (2009 - present)	Body	RLS (Rain / driving-lights sensor)	V	V	V	V																																						V						
Z Series	Z4 (E89) (2009 - present)	Body	SMFA (Seat module - driver)	V	V	V	V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Drive	DME (Engine electronics)	V	V	V	V						V																																						
Z Series	Z4 (E85 / E86) (2003 - 2008)	Drive	EGS(Electronic transmission control)	V	V	V	V														V	V																													
Z Series	Z4 (E85 / E86) (2003 - 2008)	Drive	EKPS (Electric fuel pump)	V	V	V	V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Drive	EWS (Electronic immobilizer)	V	V		V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Chassis	DSC (Dynamic stability control)	V	V	V	V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Chassis	EPS (Electronic Power Steering)	V	V		V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Chassis	LWS (Steering angle sensor)	V	V		V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Chassis	RDC (Tyre pressure control)	V	V		V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	ACSM (Crash Safety Module)	V	V		V																														V														
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	CDC (CD Changer)	V		V	V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	CVM (Convertible-top module)	V	V		V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	GM (Basic module)	V	V	V	V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	IHKA (Automatic heating/air conditioning)	V	V	V	V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	KOMBI (Instrument cluster)	V	V	V	V	V																																											
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	LSZ (Light switching centre)	V	V	V	V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	MFL (Multifunction steering wheel)		V		V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	RAD (Radio)	V	V	V	V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	RLS (Rain/driving-lights sensor)	V	V		V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	SIM (Safety and Information Module)	V	V	V	V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	SBSL (Satellite, B-pillar, left)	V	V		V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	SBSR (Satellite, B-pillar, right)	V	V		V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	SMF (Seat memory, driver)	V	V	V	V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	SZM (Centre console control panel)	V	V		V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	TOP-DSP2 (Digital Sound Processor)	V	V		V																																												
Z Series	Z4 (E85 / E86) (2003 - 2008)	Body	VM (Video module)	V		V	V																																												
Z Series	Z8 (E52) (2000 - 2003)	Drive	DME	V	V	V																																													
Z Series	Z8 (E52) (2000 - 2003)	Drive	EWS (Electronic immobilizer)	V	V																																														
Z Series	Z8 (E52) (2000 - 2003)	Chassis	ABS(Anti-lock Brake System)	V	V	V																																													

Series	Chassis type	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	Service (CBS) Reset	Register battery replacement	CBS Reset (manual)	Abbreviations	CAS Reset	Clear adaptations	Reset VANOS adaptation values	Valvetronic adaptation limit positions	Start-up Valvetronic	Injector quantity adjustment	Regeneration, particulate filter	Clear mixture adaptation	CO adjustment	Display and reset adaptation values	Resetting adaption functions	Oil change	Reset learning function	Learn sensor parameters	Learn sensor zero point	Bleed	Brake line check	Lateral acceleration sensor	Pressure sensors	Steering Angle Sensor Adjustment	Rotation Rate Sensor	Adaptation of idle speed	Basic setting, exhaust-gas recirculation	Start quantity correction	Initial operation	Workshop mode	Coding data	Delete the personal profile	Run-in protection for A/C compressor	Initialise power window regulators	Initialise the headlight driver module and teach in LEDs in headlight	Driver's seat standardisation	Calibration	Initialise slide/tilt sunroof	Initialise rain sensor	Delivery position	Rear module emergency access	Remote key initialisation	Sensitivity level	Handset log-on
Z Series	Z8 (E52) (2000 - 2003)	Chassis	LWS (Steering angle sensor)	V	V																																														
Z Series	Z8 (E52) (2000 - 2003)	Body	IHKA/IHKR(Heater/Air Conditioning)	V	V	V																																													
Z Series	Z8 (E52) (2000 - 2003)	Body	IKE/IKI/KOMBI(Instrument cluster)	V	V	V		V																																											
Z Series	Z8 (E52) (2000 - 2003)	Body	SRS(Airbag)	V	V																																														
Z Series	Z8 (E52) (2000 - 2003)	Body	GM (Basic module)	V	V	V																																													
Z Series	Z3 (E36) (1996 - 2002)	Support Function	Service reset(oil/time/distance)	V	V	V		V																																											
Z Series	Z3 (E36) (1996 - 2002)	Support Function	Clear adaptation(Engine)	V	V	V															V																														
Z Series	Z3 (E36) (1996 - 2002)	Support Function	Clear adaptation(Transmission)	V	V	V															V																														
Z Series	Z3 (E36) (1996 - 2002)	Drive	DME(Engine)	V	V	V															V																														
Z Series	Z3 (E36) (1996 - 2002)	Drive	EGS(Electronic transmission control)	V	V	V															V																														
Z Series	Z3 (E36) (1996 - 2002)	Drive	EWS (Electronic immobilizer)	V	V																																														
Z Series	Z3 (E36) (1996 - 2002)	Drive	EML(Elec. Throttle)	V	V																																														
Z Series	Z3 (E36) (1996 - 2002)	Chassis	ABS(Anti-lock Brake System)	V	V	V																																													
Z Series	Z3 (E36) (1996 - 2002)	Chassis	LWS (Steering angle sensor)	V	V																																														
Z Series	Z3 (E36) (1996 - 2002)	Chassis	EHC-EDC(Signal-axle air suspension)	V	V																																														
Z Series	Z3 (E36) (1996 - 2002)	Chassis	EHC-EDC(Signal-axle air suspension)	V	V																																														
Z Series	Z3 (E36) (1996 - 2002)	Body	BM(On-board monitor)	V																																															
Z Series	Z3 (E36) (1996 - 2002)	Body	CVM (Convertible-top module)	V	V																																														
Z Series	Z3 (E36) (1996 - 2002)	Body	IHKA/IHKR(Heater/Air Conditioning)	V	V	V																																													
Z Series	Z3 (E36) (1996 - 2002)	Body	IKE/IKI/KOMBI(Instrument cluster)	V	V	V		V																																											
Z Series	Z3 (E36) (1996 - 2002)	Body	LSZ/LCM(Light switching center)	V	V	V																																													
Z Series	Z3 (E36) (1996 - 2002)	Body	PDC (Park Distance Control)	V	V	V																																													
Z Series	Z3 (E36) (1996 - 2002)	Body	RAD (Radio)	V	V	V																																													
Z Series	Z3 (E36) (1996 - 2002)	Body	SES(Language-input system)	V																																															
Z Series	Z3 (E36) (1996 - 2002)	Body	SHD (Sliding/tilting sunroof)	V																																															
Z Series	Z3 (E36) (1996 - 2002)	Body	SMF (Seat memory, driver)	V	V	V																																													
Z Series	Z3 (E36) (1996 - 2002)	Body	SRS(Airbag)	V	V																																														
Z Series	Z3 (E36) (1996 - 2002)	Body	GM (Basic module)	V	V	V																																													
Z Series	Z1 (E30) (1989 - 1991)	Drive	DME	V	V	V																																													
Z Series	Z1 (E30) (1989 - 1991)	Chassis	ABS(Anti-lock Brake System)	V	V	V																																													
Z Series	Z1 (E30) (1989 - 1991)	Body	IHKA/IHKR(Heater/Air Conditioning)	V	V	V																																													
Z Series	Z1 (E30) (1989 - 1991)	Body	IKE/IKI/KOMBI(Instrument cluster)	V	V	V		V																																											
Z Series	Z1 (E30) (1989 - 1991)	Body	SRS(Airbag)	V	V																																														

Model	System1	Type1	DTC	CURR	ACT	ECUINFOR	Customer Specific Data	Vehicle Identification Number	Production Date	Input Safety Code	Set Safety Code	Read immobilizer to EMS	Read EMS to immobilizer	Key learning	Key erasing	Immobilizer reset	EMS reset	Configurate Lamp	Reset Car Maintenance	Reset ECU
Tiggo 3	Engine	Delphi System 2.0L/2.4L	V	V	V	V														
Tiggo 3	Engine	UAES System 1.6L	V	V	V	V														
Tiggo 3	Engine	UAES System 2.0L	V	V	V	V														
Tiggo 3	SRS	Hyundai SRS	V			V														
Tiggo 3	SRS	Continental SRS	V	V	V	V	V	V	V											
Tiggo 3	ABS	MGH 25	V	V	V	V														
Tiggo 3	ABS	MGH 60	V	V	V	V														
Tiggo 3	ITM	All	V			V														
Tiggo 3	Immobilizer	All	V	V		V				V	V	V	V	V	V	V	V			
A1	Engine	UAES System	V	V	V	V														
A1	ABS	MGH 60	V	V	V	V														
A1	SRS	All	V	V		V														
A1	BCM	ATECH BCM	V	V																
A1	BCM	Zhongsheng	V	V																
A1	ICM	ATECH	V	V	V	V														
A1	ICM	AMT Series	V	V	V	V														
A1	ImmVbilizer	Shaihai Shiye	V	V		V				V	V	V	V	V	V	V	V			
A1	ImmVbilizer	Delphi	V	V		V				V	V	V	V	V	V	V	V			
A3	Engine	UAES 1.6 Engine System	V	V	V	V														
A3	Engine	UAES 1.6 VVT Engine System	V	V	V	V														
A3	ABS	All	V	V																
A3	SRS	All	V			V														
A3	BCM	All	V		V															
A3	ICM	All	V	V	V	V												V	V	V
QQ3	Engine	MT Siemens 472 System	V	V	V	V														

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	System Identification	System Information	Read BCM Security code	PIM install(GEN III)	PIM install(V8 GEN IV)	Program Variant Configuration	BCM Security Information and Program	BCM Link to PCM(PIM)	Reset PIM	Reset ECM	TPMS Initialization	Idle learn	Throttle body relearn	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	VX_Power Balance	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	THROTTLE BODY RELEARN	Calibration Steering Angle Sensor	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote
MAGNUS	POWERTRAIN	2.0 SOHC	V	V	V	V																																													
MAGNUS	POWERTRAIN	2.0 DOHC	V	V	V	V																																													
MAGNUS	POWERTRAIN	2.0 L6	V	V	V	V																																													
MAGNUS	POWERTRAIN	2.5 L6	V	V	V	V																																													
MAGNUS	POWERTRAIN	AUTO T/M	V	V	V	V																																													
MAGNUS	BODY	AIR BAG	V																																																
MAGNUS	BODY	ISU	V	V	V	V																																													
MAGNUS	CHASSIS	ABS	V	V	V	V																																													
MAGNUS	CHASSIS	SPSS DELPHI	V																																																
MAGNUS	CHASSIS	SPSS MANDO(L6)	V	V	V	V																																													
MATIZ/SPARK(M100)	POWERTRAIN	0.8S EOBD	V	V	V	V																																													
MATIZ/SPARK(M100)	POWERTRAIN	1.0S EOBD	V	V	V	V																																													
MATIZ/SPARK(M100)	BODY	AIR BAG	V			V																																													
MATIZ/SPARK(M100)	CHASSIS	ABS	V	V	V	V																																													
MATIZ/SPARK(M200)	POWERTRAIN	0.8S(EURO-II and ECE83)	V	V	V	V																																													
MATIZ/SPARK(M200)	POWERTRAIN	0.8S(EURO-III and IV or w/EOBD)	V	V	V	V																																													
MATIZ/SPARK(M200)	POWERTRAIN	1.0S(EURO-II and ECE83)	V	V	V	V																																													
MATIZ/SPARK(M200)	POWERTRAIN	1.0S(EURO-III and IV or w/EOBD)	V	V	V	V																																													
MATIZ/SPARK(M200)	POWERTRAIN	AUTO T/M	V	V	V	V																																													
MATIZ/SPARK(M200)	BODY	AIR BAG	V			V																																													
MATIZ/SPARK(M200)	CHASSIS	ABS	V	V	V	V																																													
SPARK(M300)	POWERTRAIN	Engine control unit(1.0L LEB)	V	V	V	V																																													
SPARK(M300)	POWERTRAIN	Engine control unit(1.0L LMT)	V	V	V	V																																													
SPARK(M300)	POWERTRAIN	ENGINE	V																																																
SPARK(M300)	POWERTRAIN	ENGINE LPG	V																																																
SPARK(M300)	POWERTRAIN	TCM	V	V	V	V																																													
SPARK(M300)	Chassis	EBCM(Electronic Brake Control Module)	V	V	V	V																																													
SPARK(M300)	Chassis	Steering wheel angle sensor module	V			V																																													
SPARK(M300)	Chassis	Multi axis acceleration sensor module	V			V																																													
SPARK(M300)	BODY	SDM	V	V		V																																													
SPARK(M300)	BODY	IPC	V	V	V	V																																													
SPARK(M300)	BODY	Keyless Entry		V																																															
LEZZO/TACUMA	POWERTRAIN 05	1.6 DOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 05	1.8 DOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 05	2.0 DOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 05	AUTO T/M	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 06	1.6 DOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 06	1.8 DOHC	V	V	V	V																																													

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	System Identification	System Information	Read BCM Security code	PIM install(GEN III)	PIM install(V8 GEN IV)	Program Variant Configuration	BCM Security Information and Program	BCM Link to PCM(PIM)	Reset PIM	Reset ECM	TPMS Initialization	Idle learn	Throttle body relearn	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	VX_Power Balance	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	THROTTLE BODY RELEARN	Calibration Steering Angle Sensor	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote
LEZZO/TACUMA	POWERTRAIN 06	2.0 DOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 06	AUTO T/M	V	V	V	V																																													
LEZZO/TACUMA	BODY	AIR BAG	V	V		V																																													
LEZZO/TACUMA	CHASSIS	ABS	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 05	1.2 SOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 05	1.4 SOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 05	1.4 DOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 05	1.5 SOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 05	1.6 DOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 05	AUTO T/M	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 06	1.2 SOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 06	1.4 SOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 06	1.4 DOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 06	1.5 SOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 06	1.6 DOHC	V	V	V	V																																													
LEZZO/TACUMA	POWERTRAIN 06	AUTO T/M	V	V	V	V																																													
LEZZO/TACUMA	BODY	AIR BAG	V																																																
LEZZO/TACUMA	CHASSIS	ABS	V	V	V	V																																													
KALOS/AVEO	POWERTRAIN 05	1.2 SOHC	V	V	V	V																																													
KALOS/AVEO	POWERTRAIN 05	1.4 SOHC	V	V	V	V																																													
KALOS/AVEO	POWERTRAIN 05	1.4 DOHC	V	V	V	V																																													
KALOS/AVEO	POWERTRAIN 05	1.5 SOHC	V	V	V	V																																													
KALOS/AVEO	POWERTRAIN 05	1.6 DOHC	V	V	V	V																																													
KALOS/AVEO	POWERTRAIN 05	AUTO T/M	V	V	V	V																																													
KALOS/AVEO	POWERTRAIN 06	1.2 SOHC	V	V	V	V																																													
KALOS/AVEO	POWERTRAIN 06	1.4 SOHC	V	V	V	V																																													
KALOS/AVEO	POWERTRAIN 06	1.4 DOHC	V	V	V	V																																													
KALOS/AVEO	POWERTRAIN 06	1.5 SOHC	V	V	V	V																																													
KALOS/AVEO	POWERTRAIN 06	1.6 DOHC	V	V	V	V																																													
KALOS/AVEO	POWERTRAIN 06	AUTO T/M	V	V	V	V																																													
KALOS/AVEO	BODY	AIR BAG	V																																																
KALOS/AVEO	CHASSIS	ABS	V	V	V	V																																													
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.4 DOHC	V	V	V	V																																													
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.5 DOHC	V	V	V	V																																													
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.6 DOHC	V	V	V	V																																													
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.8 DOHC	V	V	V	V																																													
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	AUTO T/M	V	V	V	V																																													
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.4 DOHC	V	V	V	V																																													

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	System Identification	System Information	Read BCM Security code	PIM install(GEN III)	PIM install(V8 GEN IV)	Program Variant Configuration	BCM Security Information and Program	BCM Link to PCM(PIM)	Reset PIM	Reset ECM	TPMS Initialization	Idle learn	Throttle body relearn	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	VX_Power Balance	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	THROTTLE BODY RELEARN	Calibration Steering Angle Sensor	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.5 DOHC	V	V	V	V																																														
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.6 DOHC	V	V	V	V																																														
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.8 DOHC	V	V	V	V																																														
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	AUTO T/M	V	V	V	V																																														
NUBIRA/LACETTI/OPTRA(J200)	BODY	AIR BAG	V																																																	
NUBIRA/LACETTI/OPTRA(J200)	CHASSIS	ABS	V	V	V	V																																														
NUBIRA/LACETTI/OPTRA(J200)	CHASSIS	SSPS	V	V	V	V																																														
AVEO(T250)	POWERTRAIN	1.2 SOHC	V	V	V	V																																														
AVEO(T250)	POWERTRAIN	1.4 SOHC	V	V	V	V																																														
AVEO(T250)	POWERTRAIN	1.4 DOHC	V	V	V	V																																														
AVEO(T250)	POWERTRAIN	1.5 SOHC	V	V	V	V																																														
AVEO(T250)	POWERTRAIN	1.6 DOHC	V	V	V	V																																														
AVEO(T250)	POWERTRAIN	AUTO T/M	V	V	V	V																																														
AVEO(T250)	BODY	AIR BAG	V	V		V																																														
AVEO(T250)	CHASSIS	ABS	V	V	V	V																																														
EPICA/TOSCA	POWERTRAIN	2.0 DOHC	V	V	V	V																																														
EPICA/TOSCA	POWERTRAIN	2.5 DOHC	V	V	V	V																																														
EPICA/TOSCA	POWERTRAIN	Diesel	V	V	V	V																																														
EPICA/TOSCA	POWERTRAIN	A/TAisin 5	V	V	V	V																																														
EPICA/TOSCA	POWERTRAIN	A/TGF6	V	V	V	V																																														
EPICA/TOSCA	BODY	AIR BAG	V	V		V																																														
EPICA/TOSCA	BODY	ISU	V	V	V	V																																														
EPICA/TOSCA	CHASSIS	ABS	V	V	V	V																																														
EPICA/TOSCA	CHASSIS	SSPS	V	V	V	V																																														
CAPTIVA	POWERTRAIN	ECM(DIESEL)	V	V	V	V																																														
CAPTIVA	POWERTRAIN	ECM(2.4D)	V	V	V	V																																														
CAPTIVA	POWERTRAIN	ECM(3.2D)	V	V	V	V																																														
CAPTIVA	POWERTRAIN	TCM	V	V	V	V																																														
CAPTIVA	BODY	SDM	V	V																																																
CAPTIVA	BODY	IPC	V	V	V																																															
CAPTIVA	BODY	BCM	V	V	V	V																																														
CAPTIVA	BODY	VTD	V	V		V																																														
CAPTIVA	BODY	RFA	V	V		V																																														
CAPTIVA	CHASSIS	EBCM(ABS/ESC)	V	V	V	V																																														
CAPTIVA	CHASSIS	TCCM	V	V		V																																														
Captiva 5/7	Powertrain	Engine control module(2.2L LNQ)	V	V	V	V																																														
Captiva 5/7	Powertrain	Engine control module(2.4L LE5)	V	V	V	V																																														
Captiva 5/7	Powertrain	Engine control module(2.4L LE9)	V	V	V	V																																														

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	System Identification	System Information	Read BCM Security code	PIM install(GEN III)	PIM install(V8 GEN IV)	Program Variant Configuration	BCM Security Information and Program	BCM Link to PCM(PIM)	Reset PIM	Reset ECM	TPMS Initialization	Idle learn	Throttle body relearn	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	VX_Power Balance	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	THROTTLE BODY RELEARN	Calibration Steering Angle Sensor	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote
Captiva 5/7	Powertrain	Engine control module(3.0L LF1)	V	V	V	V																																													
Captiva 5/7	Powertrain	Transmission control module	V	V	V	V																																													
Captiva 5/7	Powertrain	Fuel pump control module	V																																																
Captiva 5/7	Chassis	Electronic brake control module	V	V	V	V																																													
Captiva 5/7	Chassis	Parking brake control module	V	V	V	V																																													
Captiva 5/7	Chassis	Rear differential clutch control module	V	V		V																																													
Captiva 5/7	Body	Body control module	V	V	V	V																																													
Captiva 5/7	Body	Inflatable restraint sensing and diagnostic module	V	V		V																																													
Captiva 5/7	Body	Instrument panel cluster	V	V		V																																													
Captiva 5/7	Body	HVAC control module	V	V	V	V																																													
Captiva 5/7	Body	Remote control door lock receiver	V	V	V	V																																													
Captiva 5/7	Body	Theft deterrent module	V	V		V																																													
Captiva 5/7	Body	Parking assist control module	V	V		V																																													
Captiva 5/7	Information	Radio	V																																																
CRUZE	POWERTRAIN	Engine control module(1.4L LUJ))	V	V	V	V																																													
CRUZE	POWERTRAIN	Engine control module(2.0L LNP)	V	V	V	V																																													
CRUZE	POWERTRAIN	Engine Control Module-Diesel	V	V	V	V																																													
CRUZE	POWERTRAIN	Engine Control Module	V	V	V	V																																													
CRUZE	POWERTRAIN	Fuel Pump Control Module	V																																																
CRUZE	POWERTRAIN	Transmission Control Module	V	V	V	V																																													
CRUZE	CHASSIS	Electronic Brake Control Module With TCC	V	V	V	V																																													
CRUZE	CHASSIS	Electronic Brake Control Module Without TCC	V	V	V	V																																													
CRUZE	CHASSIS	Electric Power Steering Control Module	V																																																
CRUZE	CHASSIS	Steering wheel angle sensor module	V			V																																													
CRUZE	BODY	Body Control Module	V	V	V	V																																													
CRUZE	BODY	SDM(SRS Airbag)	V	V	V	V																																													
CRUZE	BODY	Passenger Presence Module	V																																																
CRUZE	BODY	Instrument Panel Cluster	V	V	V	V																																													
CRUZE	BODY	Heating Ventilating and Air Conditioning-Other	V	V	V	V																																													
CRUZE	BODY	Heating Ventilating and Air Conditioning-Manual	V	V	V	V																																													
CRUZE	BODY	Front Seat Heating Control Module	V	V	V	V																																													
CRUZE	BODY	Parking Assist Control Module	V			V																																													
CRUZE	BODY	Passive Entry Passive Start	V																																																
CRUZE	BODY	Steering Column Lock Control Module	V			V																																													
CRUZE	BODY	Multi axis acceleration sensor module	V			V																																													
CRUZE	Infotainment	Radio	V		V																																														
CRUZE	Infotainment	Telematics Communication Interface Control Module	V																																																
Lacetti Premiere	Powertrain	Diesel	V	V	V	V																																													

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	System Identification	System Information	Read BCM Security code	PIM install(GEN III)	PIM install(V8 GEN IV)	Program Variant Configuration	BCM Security Information and Program	BCM Link to PCM(PIM)	Reset PIM	Reset ECM	TPMS Initialization	Idle learn	Throttle body relearn	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	VX_Power Balance	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	THROTTLE BODY RELEARN	Calibration Steering Angle Sensor	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote
Lacetti Premiere	Powertrain	FAM1	V	V	V	V																																													
Lacetti Premiere	Powertrain	FPCM	V	V	V	V																																													
Lacetti Premiere	Powertrain	GF6 TCM	V	V	V	V																																													
Lacetti Premiere	Chassis	EBCM	V	V	V	V																																													
Lacetti Premiere	Chassis	EPS	V	V	V	V																																													
Lacetti Premiere	Body	BCM	V	V	V	V																																													
Lacetti Premiere	Body	SDM	V	V	V	V																																													
Lacetti Premiere	Body	IPC	V	V	V	V																																													
Lacetti Premiere	Body	HVAC	V	V	V	V																																													
Lacetti Premiere	Body	HVSM-F	V	V	V	V																																													
Lacetti Premiere	Body	PAM	V	V	V	V																																													
Lacetti Premiere	Body	PEPS	V	V	V	V																																													
Lacetti Premiere	Body	ESCL	V	V	V	V																																													
Lacetti Premiere	Infortainment	IRC	V																																																
Lacetti Premiere	Infortainment	PDIM	V																																																
NABIRA(Zafira-A)	Engine	Z 18 XE	V	V	V	V																																													
NABIRA(Zafira-A)	Engine	Z 22 SE	V	V	V	V																																													
NABIRA(Zafira-A)	Transmission	AF 13-II/17/20/22	V	V	V	V																																													
NABIRA(Zafira-A)	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																													
NABIRA(Zafira-A)	Chassis	ABS 5.3/5.4 +TC	V	V	V	V																																													
NABIRA(Zafira-A)	Chassis	ESP	V	V	V	V																																													
NABIRA(Zafira-A)	Chassis	Electronic Power Steering	V	V		V																																													
NABIRA(Zafira-A)	Body	Immobiliser	V	V	V	V																																													
NABIRA(Zafira-A)	Body	SRS Airbag	V	V	V	V																																													
NABIRA(Zafira-A)	Body	Instrument	V	V	V	V																																													
NABIRA(Zafira-A)	Body	Engine Cooling Module	V	V	V	V																																													
NABIRA(Zafira-A)	Body	Add On Heater	V	V	V	V																																													
NABIRA(Zafira-A)	Body	Electronic Climate Control	V	V	V	V																																													
NABIRA(Zafira-A)	Body	Central Door Lock	V	V	V	V																																													
NABIRA(Zafira-A)	Infortainment System	Trip Info Display	V	V	V	V																																													
NABIRA(Zafira-A)	Infortainment System	Multi Info Display	V	V	V	V																																													
SAIL	Powertrain	1.4L LCU	V	V	V	V																																													
SAIL	Powertrain	Transmission	V		V	V																																													
SAIL	Body	AIR BAG	V	V	V	V																																													
SAIL	Chassis	ABS	V		V	V																																													
SONIC	Powertrain	Engine 1.6L LDE	V	V	V	V																																													
SONIC	Chassis	Electronic brake control module	V	V	V	V																																													
SONIC	Body	Immobiliser																																																	

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	System Identification	System Information	Read BCM Security code	PIM install(GEN III)	PIM install(V8 GEN IV)	Program Variant Configuration	BCM Security Information and Program	BCM Link to PCM(PIM)	Reset PIM	Reset ECM	TPMS Initialization	Idle learn	Throttle body relearn	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	VX_Power Balance	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	THROTTLE BODY RELEARN	Calibration Steering Angle Sensor	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote
SONIC	Body	Body control module	V	V	V	V																																													
SONIC	Body	SRS Airbag	V	V	V	V																																													
SONIC	Body	Instrument	V	V	V	V																																													
N200/N300	N200	Engine	V	V	V	V																																													
N200/N300	N200	Electronic Brake Control Module	V	V	V																																														
N200/N300	N200	SRS Airbag	V	V		V																																													
N200/N300	N300	Engine	V	V	V	V																																													
N200/N300	N300	Electronic Brake Control Module	V	V	V																																														
N200/N300	N300	SRS Airbag	V	V		V																																													
Orlando	16 PIN	Engine	V	V	V	V																																													
Orlando	16 PIN	Transmission	V	V	V	V																																													
Orlando	16 PIN	Fuel Injector Control Module	V	V	V	V																																													
Orlando	16 PIN	Electronic Brake Control Module	V	V	V	V																																													
Orlando	16 PIN	Parking Brake Control Module	V			V																																													
Orlando	16 PIN	Multi-Axis Acceleration Sensor Module	V			V																																													
Orlando	16 PIN	Power Steering Control Module	V																																																
Orlando	16 PIN	Steering Wheel Angle Sensor Module	V			V																																													
Orlando	16 PIN	Body Control Module	V	V	V	V																																													
Orlando	16 PIN	SDM(SRS Airbag)	V	V		V																																													
Orlando	16 PIN	Instrument Cluster	V	V	V	V																																													
Orlando	16 PIN	Trailer Interface Control Module	V			V																																													
Orlando	16 PIN	Radio	V	V	V	V																																													
Colorado/Colorado7	Engine	2.5L LVN Auto	V	V	V	V																																													
Colorado/Colorado7	Engine	2.5L LVN Manual	V	V	V	V																																													
Colorado/Colorado7	Engine	2.8L Diesel(LWH)	V	V	V	V																																													
Colorado/Colorado7	Transmission	Auto transmission	V	V	V	V																																													
Colorado/Colorado7	Chassis	EBCM(Electronic brake control module)	V	V	V	V																																													
Colorado/Colorado7	Chassis	Transfer case module	V	V	V	V																																													
Colorado/Colorado7	Chassis	Multi-Axis acceleration sensor module	V			V																																													
Colorado/Colorado7	Chassis	Steering wheel angle sensor module	V			V																																													
Colorado/Colorado7	Body	Immobilizer																																																	
Colorado/Colorado7	Body	SDM(Inflatable restraint sensing and diagnostic module)	V	V	V	V																																													
Colorado/Colorado7	Body	2.5L LVN Body control module	V	V	V	V																																													
Colorado/Colorado7	Body	BCM(Body control module)	V	V	V	V																																													
Colorado/Colorado7	Body	IPC(Instrument cluster)	V	V	V	V																																													

Vehicle	System 1	System 2	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Actuator Recalibration	Read configuration	Fuel injector learn	Touch point adaptation	Fuel Rail Pressure Sensor Learn	Engine oil life reset	Transmission Adaptive Pressure Reset	Range actuator learn	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Key programming	Brake pedal position sensor learn	CAN Bus Configuration Learn	Clutch Fast Learn	Reset TCM Adaption Value	Solenoid Cleaning	Setup New SDM	SDM Reset	Adapt Reset	Power Mode	Brake Pedal	Odd Meter Reset	VIN Write	History of alarm	Button diagnosis	Transmitter coding	Park brake calibration	Steering angle sensor learn	Crankshaft position variant learn	Crankshaft position variant learn	Idle learn	Brake pedal position sensor learn	Fuel trim reset
MAGNUS	POWERTRAIN	2.0 SOHC																																																	
MAGNUS	POWERTRAIN	2.0 DOHC																																																	
MAGNUS	POWERTRAIN	2.0 L6																																																	
MAGNUS	POWERTRAIN	2.5 L6																																																	
MAGNUS	POWERTRAIN	AUTO T/M																																																	
MAGNUS	BODY	AIR BAG																																																	
MAGNUS	BODY	ISU																																																	
MAGNUS	CHASSIS	ABS																																																	
MAGNUS	CHASSIS	SPSS DELPHI																																																	
MAGNUS	CHASSIS	SPSS MANDO(L6)																																																	
MATIZ/SPARK(M100)	POWERTRAIN	0.8S EOBD																																																	
MATIZ/SPARK(M100)	POWERTRAIN	1.0S EOBD																																						V											
MATIZ/SPARK(M100)	BODY	AIR BAG																																																	
MATIZ/SPARK(M100)	CHASSIS	ABS																																																	
MATIZ/SPARK(M200)	POWERTRAIN	0.8S(EURO-II and ECE83)																																																	
MATIZ/SPARK(M200)	POWERTRAIN	0.8S(EURO-III and IV or w/EOBD)																																																	
MATIZ/SPARK(M200)	POWERTRAIN	1.0S(EURO-II and ECE83)																																																	
MATIZ/SPARK(M200)	POWERTRAIN	1.0S(EURO-III and IV or w/EOBD)																																																	
MATIZ/SPARK(M200)	POWERTRAIN	AUTO T/M																																																	
MATIZ/SPARK(M200)	BODY	AIR BAG																																																	
MATIZ/SPARK(M200)	CHASSIS	ABS																																																	
SPARK(M300)	POWERTRAIN	Engine control unit(1.0L LEB)																																						V						V					V
SPARK(M300)	POWERTRAIN	Engine control unit(1.0L LMT)																																						V						V					V
SPARK(M300)	POWERTRAIN	ENGINE																																																	
SPARK(M300)	POWERTRAIN	ENGINE LPG																																																	
SPARK(M300)	POWERTRAIN	TCM																													V	V	V							V										
SPARK(M300)	Chassis	EBCM(Electronic Brake Control Module)																																						V											
SPARK(M300)	Chassis	Steering wheel angle sensor module																									V	V																							
SPARK(M300)	Chassis	Multi axis acceleration sensor module																							V	V																									
SPARK(M300)	BODY	SDM																																V	V	V				V											
SPARK(M300)	BODY	IPC																																					V	V											
SPARK(M300)	BODY	Keyless Entry																																					V		V	V	V								
LEZZO/TACUMA	POWERTRAIN 05	1.6 DOHC																																						V											
LEZZO/TACUMA	POWERTRAIN 05	1.8 DOHC																																						V											
LEZZO/TACUMA	POWERTRAIN 05	2.0 DOHC																																																	
LEZZO/TACUMA	POWERTRAIN 05	AUTO T/M																																																	
LEZZO/TACUMA	POWERTRAIN 06	1.6 DOHC																																																	
LEZZO/TACUMA	POWERTRAIN 06	1.8 DOHC																																																	

Vehicle	System 1	System 2	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Actuator Recalibration	Read configuration	Fuel injector learn	Touch point adaptation	Fuel Rail Pressure Sensor Learn	Engine oil life reset	Transmission Adaptive Pressure Reset	Range actuator learn	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Key programming	Brake pedal position sensor learn	CAN Bus Configuration Learn	Clutch Fast Learn	Reset TCM Adaption Value	Solenoid Cleaning	Setup New SDM	SDM Reset	Adapt Reset	Power Mode	Brake Pedal	Odd Meter Reset	VIN Write	History of alarm	Button diagnosis	Transmitter coding	Park brake calibration	Steering angle sensor learn	Crankshaft position variant learn	Crankshaft position variant learn	Idle learn	Brake pedal position sensor learn	Fuel trim reset
LEZZO/TACUMA	POWERTRAIN 06	2.0 DOHC																																																	
LEZZO/TACUMA	POWERTRAIN 06	AUTO T/M																																																	
LEZZO/TACUMA	BODY	AIR BAG																																																	
LEZZO/TACUMA	CHASSIS	ABS																																																	
LEZZO/TACUMA	POWERTRAIN 05	1.2 SOHC																																					V												
LEZZO/TACUMA	POWERTRAIN 05	1.4 SOHC																																																	
LEZZO/TACUMA	POWERTRAIN 05	1.4 DOHC																																																	
LEZZO/TACUMA	POWERTRAIN 05	1.5 SOHC																																																	
LEZZO/TACUMA	POWERTRAIN 05	1.6 DOHC																																																	
LEZZO/TACUMA	POWERTRAIN 05	AUTO T/M																																																	
LEZZO/TACUMA	POWERTRAIN 06	1.2 SOHC																																																	
LEZZO/TACUMA	POWERTRAIN 06	1.4 SOHC																																																	
LEZZO/TACUMA	POWERTRAIN 06	1.4 DOHC																																																	
LEZZO/TACUMA	POWERTRAIN 06	1.5 SOHC																																																	
LEZZO/TACUMA	POWERTRAIN 06	1.6 DOHC																																																	
LEZZO/TACUMA	POWERTRAIN 06	AUTO T/M																																																	
LEZZO/TACUMA	BODY	AIR BAG																																																	
LEZZO/TACUMA	CHASSIS	ABS																																																	
KALOS/AVEO	POWERTRAIN 05	1.2 SOHC																																					V												
KALOS/AVEO	POWERTRAIN 05	1.4 SOHC																																					V												
KALOS/AVEO	POWERTRAIN 05	1.4 DOHC																																					V												
KALOS/AVEO	POWERTRAIN 05	1.5 SOHC																																					V												
KALOS/AVEO	POWERTRAIN 05	1.6 DOHC																																					V												
KALOS/AVEO	POWERTRAIN 05	AUTO T/M																																																	
KALOS/AVEO	POWERTRAIN 06	1.2 SOHC																																																	
KALOS/AVEO	POWERTRAIN 06	1.4 SOHC																																					V												
KALOS/AVEO	POWERTRAIN 06	1.4 DOHC																																					V												
KALOS/AVEO	POWERTRAIN 06	1.5 SOHC																																					V												
KALOS/AVEO	POWERTRAIN 06	1.6 DOHC																																					V												
KALOS/AVEO	POWERTRAIN 06	AUTO T/M																																																	
KALOS/AVEO	BODY	AIR BAG																																																	
KALOS/AVEO	CHASSIS	ABS																																																	
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.4 DOHC																																					V												
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.5 DOHC																																					V												
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.6 DOHC																																					V												
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.8 DOHC																																					V												
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	AUTO T/M																																																	
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.4 DOHC																																					V												

Vehicle	System 1	System 2	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Actuator Recalibration	Read configuration	Fuel injector learn	Touch point adaptation	Fuel Rail Pressure Sensor Learn	Engine oil life reset	Transmission Adaptive Pressure Reset	Range actuator learn	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Key programming	Brake pedal position sensor learn	CAN Bus Configuration Learn	Clutch Fast Learn	Reset TCM Adaption Value	Solenoid Cleaning	Setup New SDM	SDM Reset	Adapt Reset	Power Mode	Brake Pedal	Odd Meter Reset	VIN Write	History of alarm	Button diagnosis	Transmitter coding	Park brake calibration	Steering angle sensor learn	Crankshaft position variant learn	Crankshaft position variant learn	Idle learn	Brake pedal position sensor learn	Fuel trim reset
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.5 DOHC																																						V											
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.6 DOHC																																						V											
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.8 DOHC																																						V											
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	AUTO T/M																																																	
NUBIRA/LACETTI/OPTRA(J200)	BODY	AIR BAG																																																	
NUBIRA/LACETTI/OPTRA(J200)	CHASSIS	ABS																																																	
NUBIRA/LACETTI/OPTRA(J200)	CHASSIS	SSPS																																																	
AVEO(T250)	POWERTRAIN	1.2 SOHC																																																	
AVEO(T250)	POWERTRAIN	1.4 SOHC																																						V											
AVEO(T250)	POWERTRAIN	1.4 DOHC																																						V											
AVEO(T250)	POWERTRAIN	1.5 SOHC																																						V											
AVEO(T250)	POWERTRAIN	1.6 DOHC																																						V											
AVEO(T250)	POWERTRAIN	AUTO T/M																																																	
AVEO(T250)	BODY	AIR BAG																																																	
AVEO(T250)	CHASSIS	ABS																																																	
EPICA/TOSCA	POWERTRAIN	2.0 DOHC																																																	
EPICA/TOSCA	POWERTRAIN	2.5 DOHC																																																	
EPICA/TOSCA	POWERTRAIN	Diesel																																						V											
EPICA/TOSCA	POWERTRAIN	A/TAisin 5																																																	
EPICA/TOSCA	POWERTRAIN	A/TGF6																													V		V							V											
EPICA/TOSCA	BODY	AIR BAG																																																	
EPICA/TOSCA	BODY	ISU																																																	
EPICA/TOSCA	CHASSIS	ABS																																																	
EPICA/TOSCA	CHASSIS	SSPS																																																	
CAPTIVA	POWERTRAIN	ECM(DIESEL)																																						V											
CAPTIVA	POWERTRAIN	ECM(2.4D)																																																	
CAPTIVA	POWERTRAIN	ECM(3.2D)																																																	
CAPTIVA	POWERTRAIN	TCM																																																	
CAPTIVA	BODY	SDM																																	V																	
CAPTIVA	BODY	IPC																																																	
CAPTIVA	BODY	BCM																																						V											
CAPTIVA	BODY	VTD																																																	
CAPTIVA	BODY	RFA																																																	
CAPTIVA	CHASSIS	EBCM(ABS/ESC)																																																	
CAPTIVA	CHASSIS	TCCM																																																	
Captiva 5/7	Powertrain	Engine control module(2.2L LNQ)																				V																														
Captiva 5/7	Powertrain	Engine control module(2.4L LE5)																				V																									V	V	V		V
Captiva 5/7	Powertrain	Engine control module(2.4L LE9)																				V																									V	V	V		V

Vehicle	System 1	System 2	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Actuator Recalibration	Read configuration	Fuel injector learn	Touch point adaptation	Fuel Rail Pressure Sensor Learn	Engine oil life reset	Transmission Adaptive Pressure Reset	Range actuator learn	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Key programming	Brake pedal position sensor learn	CAN Bus Configuration Learn	Clutch Fast Learn	Reset TCM Adaption Value	Solenoid Cleaning	Setup New SDM	SDM Reset	Adapt Reset	Power Mode	Brake Pedal	Odd Meter Reset	VIN Write	History of alarm	Button diagnosis	Transmitter coding	Park brake calibration	Steering angle sensor learn	Crankshaft position variant learn	Crankshaft position variant learn	Idle learn	Brake pedal position sensor learn	Fuel trim reset
Captiva 5/7	Powertrain	Engine control module(3.0L LF1)																				V																								V	V	V	V	V
Captiva 5/7	Powertrain	Transmission control module																																																	
Captiva 5/7	Powertrain	Fuel pump control module																																																	
Captiva 5/7	Chassis	Electronic brake control module																																										V						
Captiva 5/7	Chassis	Parking brake control module																																									V						
Captiva 5/7	Chassis	Rear differential clutch control module																																																	
Captiva 5/7	Body	Body control module																																															V	
Captiva 5/7	Body	Inflatable restraint sensing and diagnostic module																																																
Captiva 5/7	Body	Instrument panel cluster																																																
Captiva 5/7	Body	HVAC control module																																																
Captiva 5/7	Body	Remote control door lock receiver																																																
Captiva 5/7	Body	Theft deterrent module																																																
Captiva 5/7	Body	Parking assist control module																																																
Captiva 5/7	Information	Radio																																																
CRUZE	POWERTRAIN	Engine control module(1.4L LUJ))																				V																								V	V		V	V
CRUZE	POWERTRAIN	Engine control module(2.0L LNP)																				V																													
CRUZE	POWERTRAIN	Engine Control Module-Diesel																	V																															
CRUZE	POWERTRAIN	Engine Control Module																																																
CRUZE	POWERTRAIN	Fuel Pump Control Module																																																
CRUZE	POWERTRAIN	Transmission Control Module																														V																		
CRUZE	CHASSIS	Electronic Brake Control Module With TCC																								V		V																						
CRUZE	CHASSIS	Electronic Brake Control Module Without TCC																																																
CRUZE	CHASSIS	Electric Power Steering Control Module																																																
CRUZE	CHASSIS	Steering wheel angle sensor module																									V	V																						
CRUZE	BODY	Body Control Module																																																
CRUZE	BODY	SDM(SRS Airbag)																																																
CRUZE	BODY	Passenger Presence Module																																																
CRUZE	BODY	Instrument Panel Cluster																													V																			
CRUZE	BODY	Heating Ventilating and Air Conditioning-Other																																																
CRUZE	BODY	Heating Ventilating and Air Conditioning-Manual																																																
CRUZE	BODY	Front Seat Heating Control Module																																																
CRUZE	BODY	Parking Assist Control Module																																																
CRUZE	BODY	Passive Entry Passive Start																																																
CRUZE	BODY	Steering Column Lock Control Module																																																
CRUZE	BODY	Multi axis acceleration sensor module																							V	V																								
CRUZE	Infotainment	Radio																																																
CRUZE	Infotainment	Telematics Communication Interface Control Module																																																
Lacetti Premiere	Powertrain	Diesel																																					V											

Vehicle	System 1	System 2	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Actuator Recalibration	Read configuration	Fuel injector learn	Touch point adaptation	Fuel Rail Pressure Sensor Learn	Engine oil life reset	Transmission Adaptive Pressure Reset	Range actuator learn	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Key programming	Brake pedal position sensor learn	CAN Bus Configuration Learn	Clutch Fast Learn	Reset TCM Adaption Value	Solenoid Cleaning	Setup New SDM	SDM Reset	Adapt Reset	Power Mode	Brake Pedal	Odd Meter Reset	VIN Write	History of alarm	Button diagnosis	Transmitter coding	Park brake calibration	Steering angle sensor learn	Crankshaft position variant learn	Crankshaft position variant learn	Idle learn	Brake pedal position sensor learn	Fuel trim reset
Lacetti Premiere	Powertrain	FAM1																																						V											
Lacetti Premiere	Powertrain	FPCM																																																	
Lacetti Premiere	Powertrain	GF6 TCM																													V		V							V											
Lacetti Premiere	Chassis	EBCM																																						V											
Lacetti Premiere	Chassis	EPS																																																	
Lacetti Premiere	Body	BCM																																						V											
Lacetti Premiere	Body	SDM																																	V	V	V			V											
Lacetti Premiere	Body	IPC																																																	
Lacetti Premiere	Body	HVAC																																																	
Lacetti Premiere	Body	HVSM-F																																																	
Lacetti Premiere	Body	PAM																																						V											
Lacetti Premiere	Body	PEPS																																																	
Lacetti Premiere	Body	ESCL																																																	
Lacetti Premiere	Infortainment	IRC																																																	
Lacetti Premiere	Infortainment	PDIM																																																	
NABIRA(Zafira-A)	Engine	Z 18 XE																																																	
NABIRA(Zafira-A)	Engine	Z 22 SE																																																	
NABIRA(Zafira-A)	Transmission	AF 13-II/17/20/22																																																	
NABIRA(Zafira-A)	Transmission	AF 13-II/17/20/22 CAN																																																	
NABIRA(Zafira-A)	Chassis	ABS 5.3/5.4 +TC																																																	
NABIRA(Zafira-A)	Chassis	ESP																																																	
NABIRA(Zafira-A)	Chassis	Electronic Power Steering																																																	
NABIRA(Zafira-A)	Body	Immobiliser																																																	
NABIRA(Zafira-A)	Body	SRS Airbag																																																	
NABIRA(Zafira-A)	Body	Instrument																																																	
NABIRA(Zafira-A)	Body	Engine Cooling Module																																																	
NABIRA(Zafira-A)	Body	Add On Heater																																																	
NABIRA(Zafira-A)	Body	Electronic Climate Control																																																	
NABIRA(Zafira-A)	Body	Central Door Lock																																																	
NABIRA(Zafira-A)	Infortainment System	Trip Info Display																																																	
NABIRA(Zafira-A)	Infortainment System	Multi Info Display																																																	
SAIL	Powertrain	1.4L LCU																																																	
SAIL	Powertrain	Transmission																																																	
SAIL	Body	AIR BAG																																																	
SAIL	Chassis	ABS																																																	
SONIC	Powertrain	Engine 1.6L LDE																				V																								V		V		V
SONIC	Chassis	Electronic brake control module																																																	
SONIC	Body	Immobiliser																											V																							

Vehicle	System 1	System 2	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Actuator Recalibration	Read configuration	Fuel injector learn	Touch point adaptation	Fuel Rail Pressure Sensor Learn	Engine oil life reset	Transmission Adaptive Pressure Reset	Range actuator learn	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Key programming	Brake pedal position sensor learn	CAN Bus Configuration Learn	Clutch Fast Learn	Reset TCM Adaption Value	Solenoid Cleaning	Setup New SDM	SDM Reset	Adapt Reset	Power Mode	Brake Pedal	Odd Meter Reset	VIN Write	History of alarm	Button diagnosis	Transmitter coding	Park brake calibration	Steering angle sensor learn	Crankshaft position variant learn	Crankshaft position variant learn	Idle learn	Brake pedal position sensor learn	Fuel trim reset
SONIC	Body	Body control module																																																	
SONIC	Body	SRS Airbag																																																	
SONIC	Body	Instrument																																																	
N200/N300	N200	Engine																																																	
N200/N300	N200	Electronic Brake Control Module																																																	
N200/N300	N200	SRS Airbag																																																	
N200/N300	N300	Engine																																																	
N200/N300	N300	Electronic Brake Control Module																																																	
N200/N300	N300	SRS Airbag																																																	
Orlando	16 PIN	Engine																				V																								V				V
Orlando	16 PIN	Transmission																																																	
Orlando	16 PIN	Fuel Injector Control Module																																																	
Orlando	16 PIN	Electronic Brake Control Module																																																	
Orlando	16 PIN	Parking Brake Control Module																																																	
Orlando	16 PIN	Multi-Axis Acceleration Sensor Module																							V	V																									
Orlando	16 PIN	Power Steering Control Module																																																	
Orlando	16 PIN	Steering Wheel Angle Sensor Module																									V	V																							
Orlando	16 PIN	Body Control Module																																																	
Orlando	16 PIN	SDM(SRS Airbag)																																																	
Orlando	16 PIN	Instrument Cluster																																																	
Orlando	16 PIN	Trailer Interface Control Module																																																	
Orlando	16 PIN	Radio																																																	
Colorado/Colorado7	Engine	2.5L LVN Auto																				V																													
Colorado/Colorado7	Engine	2.5L LVN Manual																				V																													
Colorado/Colorado7	Engine	2.8L Diesel(LWH)																V	V	V	V	V																													
Colorado/Colorado7	Transmission	Auto transmission																					V																												
Colorado/Colorado7	Chassis	EBCM(Electronic brake control module)																																																	
Colorado/Colorado7	Chassis	Transfer case module																						V																											
Colorado/Colorado7	Chassis	Multi-Axis acceleration sensor module																							V	V																									
Colorado/Colorado7	Chassis	Steering wheel angle sensor module																									V	V																							
Colorado/Colorado7	Body	Immobilizer																											V																						
Colorado/Colorado7	Body	SDM(Inflatable restraint sensing and diagnostic module)																																																	
Colorado/Colorado7	Body	2.5L LVN Body control module																												V																					
Colorado/Colorado7	Body	BCM(Body control module)																												V																					
Colorado/Colorado7	Body	IPC(Instrument cluster)																													V																				

Vehicle	System 1	System 2	DPF Reset	DPF Regeneration	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Clutch pedal position learn	DPF Pressure sensor learn	Fuel rail(pressure sensor) learn	DPF Reset	Engine oil life reset	EGR Cooler run time counter reset	DPF Regeneration	Fuel Trim Reset	Reset TCM Adaption Valve	Line Pressure Control	Brake Pressure Sensor Calibration Unit	Configure New Module	Driver Seat Cushion Heating	Passenger Seat Cushion Heating	CO Adjustment(Leaded Fuel Onley)	ECM Segment	TEC Adaptation	Target Wheel Adaptation Value Read	Tec Learned Value Read	MEC Clear	EBCM Type	AT(TCM) Learning Value Initialization	Air Bleeding	ECU Reset	Clutch Padal Adapt(M/T)	Fuel Efficiency Check Mode(While Inspecting)	Fuel Efficiency Driving Mode(After Inspecting)	Crank Angle Re Adapt(TEC Learn)	Reset TCM Adaption Value	Vibration Rate Sensor Adat	Sub System HS Combination Setting	Sub System ECB Combination Setting	Fault Continuation Time Check	Driver Seat SBR Setup	Passenger Seat SBR Setup	Idling RPM Check	Fuel Trim Check	DPF Recycle	Cranking RPM Check	Sub-system Combination Setup	Tire Size Setting	Steering Angle Sensor Calibration	Yaw G Sensor Calibration
MAGNUS	POWERTRAIN	2.0 SOHC							V														V		V																										
MAGNUS	POWERTRAIN	2.0 DOHC							V														V		V																										
MAGNUS	POWERTRAIN	2.0 L6							V														V		V																										
MAGNUS	POWERTRAIN	2.5 L6																																																	
MAGNUS	POWERTRAIN	AUTO T/M																												V																					
MAGNUS	BODY	AIR BAG																																																	
MAGNUS	BODY	ISU																													V																				
MAGNUS	CHASSIS	ABS																											V																						
MAGNUS	CHASSIS	SPSS DELPHI																																																	
MAGNUS	CHASSIS	SPSS MANDO(L6)																																																	
MATIZ/SPARK(M100)	POWERTRAIN	0.8S EOBD							V														V	V																											
MATIZ/SPARK(M100)	POWERTRAIN	1.0S EOBD							V														V	V																											
MATIZ/SPARK(M100)	BODY	AIR BAG																																								V									
MATIZ/SPARK(M100)	CHASSIS	ABS																											V																						
MATIZ/SPARK(M200)	POWERTRAIN	0.8S(EURO-II and ECE83)							V														V																												
MATIZ/SPARK(M200)	POWERTRAIN	0.8S(EURO-III and IV or w/EOBD)							V														V																												
MATIZ/SPARK(M200)	POWERTRAIN	1.0S(EURO-II and ECE83)							V														V																												
MATIZ/SPARK(M200)	POWERTRAIN	1.0S(EURO-III and IV or w/EOBD)							V														V																												
MATIZ/SPARK(M200)	POWERTRAIN	AUTO T/M																																																	
MATIZ/SPARK(M200)	BODY	AIR BAG																																								V									
MATIZ/SPARK(M200)	CHASSIS	ABS																											V																						
SPARK(M300)	POWERTRAIN	Engine control unit(1.0L LEB)																																																	
SPARK(M300)	POWERTRAIN	Engine control unit(1.0L LMT)																																																	
SPARK(M300)	POWERTRAIN	ENGINE																																																	
SPARK(M300)	POWERTRAIN	ENGINE LPG																																																	
SPARK(M300)	POWERTRAIN	TCM																																																	
SPARK(M300)	Chassis	EBCM(Electronic Brake Control Module)																																																	
SPARK(M300)	Chassis	Steering wheel angle sensor module																																																	
SPARK(M300)	Chassis	Multi axis acceleration sensor module																																																	
SPARK(M300)	BODY	SDM																																																	
SPARK(M300)	BODY	IPC																																																	
SPARK(M300)	BODY	Keyless Entry																																																	
LEZZO/TACUMA	POWERTRAIN 05	1.6 DOHC							V														V	V																											
LEZZO/TACUMA	POWERTRAIN 05	1.8 DOHC							V														V	V																											
LEZZO/TACUMA	POWERTRAIN 05	2.0 DOHC							V														V		V																										
LEZZO/TACUMA	POWERTRAIN 05	AUTO T/M																												V																					
LEZZO/TACUMA	POWERTRAIN 06	1.6 DOHC							V														V																												
LEZZO/TACUMA	POWERTRAIN 06	1.8 DOHC							V														V																												

Vehicle	System 1	System 2	DPF Reset	DPF Regeneration	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Clutch pedal position learn	DPF Pressure sensor learn	Fuel rail(pressure sensor) learn	DPF Reset	Engine oil life reset	EGR Cooler run time counter reset	DPF Regeneration	Fuel Trim Reset	Reset TCM Adaption Valve	Line Pressure Control	Brake Pressure Sensor Calibration Unit	Configure New Module	Driver Seat Cushion Heating	Passenger Seat Cushion Heating	CO Adjustment(Leaded Fuel Onley)	ECM Segment	TEC Adaptation	Target Wheel Adaptation Value Read	Tec Learned Value Read	MEC Clear	EBCM Type	AT(TCM) Learning Value Initialization	Air Bleeding	ECU Reset	Clutch Padal Adapt(M/T)	Fuel Efficiency Check Mode(While Inspecting)	Fuel Efficiency Driving Mode(After Inspecting)	Crank Angle Re Adapt(TEC Learn)	Reset TCM Adaption Value	Vibration Rate Sensor Adat	Sub System HS Combination Setting	Sub System ECB Combination Setting	Fault Continuation Time Check	Driver Seat SBR Setup	Passenger Seat SBR Setup	Idling RPM Check	Fuel Trim Check	DPF Recycle	Cranking RPM Check	Sub-system Combination Setup	Tire Size Setting	Steering Angle Sensor Calibration	Yaw G Sensor Calibration
LEZZO/TACUMA	POWERTRAIN 06	2.0 DOHC							V														V		V																											
LEZZO/TACUMA	POWERTRAIN 06	AUTO T/M																												V																						
LEZZO/TACUMA	BODY	AIR BAG																																																		
LEZZO/TACUMA	CHASSIS	ABS																											V																							
LEZZO/TACUMA	POWERTRAIN 05	1.2 SOHC							V														V	V																												
LEZZO/TACUMA	POWERTRAIN 05	1.4 SOHC							V														V		V																											
LEZZO/TACUMA	POWERTRAIN 05	1.4 DOHC							V														V		V																											
LEZZO/TACUMA	POWERTRAIN 05	1.5 SOHC							V														V		V																											
LEZZO/TACUMA	POWERTRAIN 05	1.6 DOHC							V														V		V																											
LEZZO/TACUMA	POWERTRAIN 05	AUTO T/M																																																		
LEZZO/TACUMA	POWERTRAIN 06	1.2 SOHC							V														V																													
LEZZO/TACUMA	POWERTRAIN 06	1.4 SOHC							V														V		V																											
LEZZO/TACUMA	POWERTRAIN 06	1.4 DOHC							V														V		V																											
LEZZO/TACUMA	POWERTRAIN 06	1.5 SOHC							V														V		V																											
LEZZO/TACUMA	POWERTRAIN 06	1.6 DOHC							V														V		V																											
LEZZO/TACUMA	POWERTRAIN 06	AUTO T/M																																																		
LEZZO/TACUMA	BODY	AIR BAG																																																		
LEZZO/TACUMA	CHASSIS	ABS																											V																							
KALOS/AVEO	POWERTRAIN 05	1.2 SOHC							V														V			V	V	V																									
KALOS/AVEO	POWERTRAIN 05	1.4 SOHC							V														V		V		V	V																									
KALOS/AVEO	POWERTRAIN 05	1.4 DOHC							V														V		V		V	V																									
KALOS/AVEO	POWERTRAIN 05	1.5 SOHC							V														V		V		V	V																									
KALOS/AVEO	POWERTRAIN 05	1.6 DOHC							V														V		V		V	V																									
KALOS/AVEO	POWERTRAIN 05	AUTO T/M																																																		
KALOS/AVEO	POWERTRAIN 06	1.2 SOHC							V														V																													
KALOS/AVEO	POWERTRAIN 06	1.4 SOHC							V														V		V		V	V																									
KALOS/AVEO	POWERTRAIN 06	1.4 DOHC							V														V		V		V	V																									
KALOS/AVEO	POWERTRAIN 06	1.5 SOHC							V														V		V		V	V																									
KALOS/AVEO	POWERTRAIN 06	1.6 DOHC							V														V		V		V	V																									
KALOS/AVEO	POWERTRAIN 06	AUTO T/M																																																		
KALOS/AVEO	BODY	AIR BAG																																																		
KALOS/AVEO	CHASSIS	ABS																											V		V																						
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.4 DOHC							V														V			V																											
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.5 DOHC							V														V			V																											
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.6 DOHC							V														V		V	V	V	V																									
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.8 DOHC							V														V		V		V	V																									
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	AUTO T/M																												V																						
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.4 DOHC							V														V																													

Vehicle	System 1	System 2	DPF Reset	DPF Regeneration	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Clutch pedal position learn	DPF Pressure sensor learn	Fuel rail(pressure sensor) learn	DPF Reset	Engine oil life reset	EGR Cooler run time counter reset	DPF Regeneration	Fuel Trim Reset	Reset TCM Adaption Valve	Line Pressure Control	Brake Pressure Sensor Calibration Unit	Configure New Module	Driver Seat Cushion Heating	Passenger Seat Cushion Heating	CO Adjustment(Leaded Fuel Onley)	ECM Segment	TEC Adaptation	Target Wheel Adaptation Value Read	Tec Learned Value Read	MEC Clear	EBCM Type	AT(TCM) Learning Value Initialization	Air Bleeding	ECU Reset	Clutch Padal Adapt(M/T)	Fuel Efficiency Check Mode(While Inspecting)	Fuel Efficiency Driving Mode(After Inspecting)	Crank Angle Re Adapt(TEC Learn)	Reset TCM Adaption Value	Vibration Rate Sensor Adat	Sub System HS Combination Setting	Sub System ECB Combination Setting	Fault Continuation Time Check	Driver Seat SBR Setup	Passenger Seat SBR Setup	Idling RPM Check	Fuel Trim Check	DPF Recycle	Cranking RPM Check	Sub-system Combination Setup	Tire Size Setting	Steering Angle Sensor Calibration	Yaw G Sensor Calibration
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.5 DOHC							V														V																												
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.6 DOHC							V														V		V																										
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.8 DOHC							V														V		V		V	V																							
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	AUTO T/M																												V																					
NUBIRA/LACETTI/OPTRA(J200)	BODY	AIR BAG																																																	
NUBIRA/LACETTI/OPTRA(J200)	CHASSIS	ABS																													V																				
NUBIRA/LACETTI/OPTRA(J200)	CHASSIS	SSPS																																																	
AVEO(T250)	POWERTRAIN	1.2 SOHC							V														V																												
AVEO(T250)	POWERTRAIN	1.4 SOHC							V														V		V		V	V																							
AVEO(T250)	POWERTRAIN	1.4 DOHC							V														V		V		V	V																							
AVEO(T250)	POWERTRAIN	1.5 SOHC							V														V		V		V	V																							
AVEO(T250)	POWERTRAIN	1.6 DOHC							V														V		V		V	V																							
AVEO(T250)	POWERTRAIN	AUTO T/M																																																	
AVEO(T250)	BODY	AIR BAG																																								V	V								
AVEO(T250)	CHASSIS	ABS																													V																				
EPICA/TOSCA	POWERTRAIN	2.0 DOHC							V														V																												
EPICA/TOSCA	POWERTRAIN	2.5 DOHC							V														V																												
EPICA/TOSCA	POWERTRAIN	Diesel																																										V	V	V	V				
EPICA/TOSCA	POWERTRAIN	A/TAisin 5																																																	
EPICA/TOSCA	POWERTRAIN	A/TGF6																																			V														
EPICA/TOSCA	BODY	AIR BAG																																								V	V								
EPICA/TOSCA	BODY	ISU																																																	
EPICA/TOSCA	CHASSIS	ABS																													V																				V	V
EPICA/TOSCA	CHASSIS	SSPS																																																	
CAPTIVA	POWERTRAIN	ECM(DIESEL)																																										V	V	V	V				
CAPTIVA	POWERTRAIN	ECM(2.4D)																																														V	V		
CAPTIVA	POWERTRAIN	ECM(3.2D)																																																	
CAPTIVA	POWERTRAIN	TCM																																																	
CAPTIVA	BODY	SDM																																																	
CAPTIVA	BODY	IPC																																																	
CAPTIVA	BODY	BCM																																																	
CAPTIVA	BODY	VTD																																																	
CAPTIVA	BODY	RFA																																																	
CAPTIVA	CHASSIS	EBCM(ABS/ESC)																													V																			V	
CAPTIVA	CHASSIS	TCCM																																																	
Captiva 5/7	Powertrain	Engine control module(2.2L LNQ)	V	V	V	V	V	V																																											
Captiva 5/7	Powertrain	Engine control module(2.4L LE5)																																																	
Captiva 5/7	Powertrain	Engine control module(2.4L LE9)																																																	

Vehicle	System 1	System 2	DPF Reset	DPF Regeneration	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Clutch pedal position learn	DPF Pressure sensor learn	Fuel rail(pressure sensor) learn	DPF Reset	Engine oil life reset	EGR Cooler run time counter reset	DPF Regeneration	Fuel Trim Reset	Reset TCM Adaption Valve	Line Pressure Control	Brake Pressure Sensor Calibration Unit	Configure New Module	Driver Seat Cushion Heating	Passenger Seat Cushion Heating	CO Adjustment(Leaded Fuel Onley)	ECM Segment	TEC Adaptation	Target Wheel Adaptation Value Read	Tec Learned Value Read	MEC Clear	EBCM Type	AT(TCM) Learning Value Initialization	Air Bleeding	ECU Reset	Clutch Padal Adapt(M/T)	Fuel Efficiency Check Mode(While Inspecting)	Fuel Efficiency Driving Mode(After Inspecting)	Crank Angle Re Adapt(TEC Learn)	Reset TCM Adaption Value	Vibration Rate Sensor Adat	Sub System HS Combination Setting	Sub System ECB Combination Setting	Fault Continuation Time Check	Driver Seat SBR Setup	Passenger Seat SBR Setup	Idling RPM Check	Fuel Trim Check	DPF Recycle	Cranking RPM Check	Sub-system Combination Setup	Tire Size Setting	Steering Angle Sensor Calibration	Yaw G Sensor Calibration
Captiva 5/7	Powertrain	Engine control module(3.0L LF1)																																																	
Captiva 5/7	Powertrain	Transmission control module																																																	
Captiva 5/7	Powertrain	Fuel pump control module																																																	
Captiva 5/7	Chassis	Electronic brake control module																																																	
Captiva 5/7	Chassis	Parking brake control module																																																	
Captiva 5/7	Chassis	Rear differential clutch control module																																																	
Captiva 5/7	Body	Body control module																																																	
Captiva 5/7	Body	Inflatable restraint sensing and diagnostic module																																																	
Captiva 5/7	Body	Instrument panel cluster																																																	
Captiva 5/7	Body	HVAC control module																																																	
Captiva 5/7	Body	Remote control door lock receiver																																																	
Captiva 5/7	Body	Theft deterrent module																																																	
Captiva 5/7	Body	Parking assist control module																																																	
Captiva 5/7	Information	Radio																																																	
CRUZE	POWERTRAIN	Engine control module(1.4L LUJ))																																																	
CRUZE	POWERTRAIN	Engine control module(2.0L LNP)	V	V	V	V	V	V																																											
CRUZE	POWERTRAIN	Engine Control Module-Diesel							V	V	V	V	V	V	V																																				
CRUZE	POWERTRAIN	Engine Control Module							V				V			V																																			
CRUZE	POWERTRAIN	Fuel Pump Control Module																																																	
CRUZE	POWERTRAIN	Transmission Control Module															V	V																																	
CRUZE	CHASSIS	Electronic Brake Control Module With TCC																	V																																
CRUZE	CHASSIS	Electronic Brake Control Module Without TCC																																																	
CRUZE	CHASSIS	Electric Power Steering Control Module																																																	
CRUZE	CHASSIS	Steering wheel angle sensor module																																																	
CRUZE	BODY	Body Control Module																																																	
CRUZE	BODY	SDM(SRS Airbag)																		V																															
CRUZE	BODY	Passenger Presence Module																																																	
CRUZE	BODY	Instrument Panel Cluster																														V																			
CRUZE	BODY	Heating Ventilating and Air Conditioning-Other																																																	
CRUZE	BODY	Heating Ventilating and Air Conditioning-Manual																																																	
CRUZE	BODY	Front Seat Heating Control Module																			V	V																													
CRUZE	BODY	Parking Assist Control Module																																																	
CRUZE	BODY	Passive Entry Passive Start																																																	
CRUZE	BODY	Steering Column Lock Control Module																																																	
CRUZE	BODY	Multi axis acceleration sensor module																																																	
CRUZE	Infotainment	Radio																																																	
CRUZE	Infotainment	Telematics Communication Interface Control Module																																																	
Lacetti Premiere	Powertrain	Diesel																																																	

Vehicle	System 1	System 2	DPF Reset	DPF Regeneration	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Clutch pedal position learn	DPF Pressure sensor learn	Fuel rail(pressure sensor) learn	DPF Reset	Engine oil life reset	EGR Cooler run time counter reset	DPF Regeneration	Fuel Trim Reset	Reset TCM Adaption Valve	Line Pressure Control	Brake Pressure Sensor Calibration Unit	Configure New Module	Driver Seat Cushion Heating	Passenger Seat Cushion Heating	CO Adjustment(Leaded Fuel Onley)	ECM Segment	TEC Adaptation	Target Wheel Adaptation Value Read	Tec Learned Value Read	MEC Clear	EBCM Type	AT(TCM) Learning Value Initialization	Air Bleeding	ECU Reset	Clutch Padal Adapt(M/T)	Fuel Efficiency Check Mode(While Inspecting)	Fuel Efficiency Driving Mode(After Inspecting)	Crank Angle Re Adapt(TEC Learn)	Reset TCM Adaption Value	Vibration Rate Sensor Adat	Sub System HS Combination Setting	Sub System ECB Combination Setting	Fault Continuation Time Check	Driver Seat SBR Setup	Passenger Seat SBR Setup	Idling RPM Check	Fuel Trim Check	DPF Recycle	Cranking RPM Check	Sub-system Combination Setup	Tire Size Setting	Steering Angle Sensor Calibration	Yaw G Sensor Calibration
Lacetti Premiere	Powertrain	FAM1																															V			V															
Lacetti Premiere	Powertrain	FPCM																																																	
Lacetti Premiere	Powertrain	GF6 TCM																																			V														
Lacetti Premiere	Chassis	EBCM																																				V	V	V										V	
Lacetti Premiere	Chassis	EPS																																																	
Lacetti Premiere	Body	BCM																																V	V																
Lacetti Premiere	Body	SDM																																																	
Lacetti Premiere	Body	IPC																														V																			
Lacetti Premiere	Body	HVAC																																																	
Lacetti Premiere	Body	HVSM-F																																																	
Lacetti Premiere	Body	PAM																																																	
Lacetti Premiere	Body	PEPS																																																	
Lacetti Premiere	Body	ESCL																														V																			
Lacetti Premiere	Infortainment	IRC																																																	
Lacetti Premiere	Infortainment	PDIM																																																	
NABIRA(Zafira-A)	Engine	Z 18 XE																																																	
NABIRA(Zafira-A)	Engine	Z 22 SE																																																	
NABIRA(Zafira-A)	Transmission	AF 13-II/17/20/22																																																	
NABIRA(Zafira-A)	Transmission	AF 13-II/17/20/22 CAN																																																	
NABIRA(Zafira-A)	Chassis	ABS 5.3/5.4 +TC																																																	
NABIRA(Zafira-A)	Chassis	ESP																																																	
NABIRA(Zafira-A)	Chassis	Electronic Power Steering																																																	
NABIRA(Zafira-A)	Body	Immobiliser																																																	
NABIRA(Zafira-A)	Body	SRS Airbag																																																	
NABIRA(Zafira-A)	Body	Instrument																																																	
NABIRA(Zafira-A)	Body	Engine Cooling Module																																																	
NABIRA(Zafira-A)	Body	Add On Heater																																																	
NABIRA(Zafira-A)	Body	Electronic Climate Control																																																	
NABIRA(Zafira-A)	Body	Central Door Lock																																																	
NABIRA(Zafira-A)	Infortainment System	Trip Info Display																																																	
NABIRA(Zafira-A)	Infortainment System	Multi Info Display																																																	
SAIL	Powertrain	1.4L LCU																																																	
SAIL	Powertrain	Transmission																																																	
SAIL	Body	AIR BAG																																																	
SAIL	Chassis	ABS																																																	
SONIC	Powertrain	Engine 1.6L LDE																																																	
SONIC	Chassis	Electronic brake control module																																																	
SONIC	Body	Immobiliser																																																	

Vehicle	System 1	System 2	DPF Reset	DPF Regeneration	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Clutch pedal position learn	DPF Pressure sensor learn	Fuel rail(pressure sensor) learn	DPF Reset	Engine oil life reset	EGR Cooler run time counter reset	DPF Regeneration	Fuel Trim Reset	Reset TCM Adaption Valve	Line Pressure Control	Brake Pressure Sensor Calibration Unit	Configure New Module	Driver Seat Cushion Heating	Passenger Seat Cushion Heating	CO Adjustment(Leaded Fuel Onley)	ECM Segment	TEC Adaptation	Target Wheel Adaptation Value Read	Tec Learned Value Read	MEC Clear	EBCM Type	AT(TCM) Learning Value Initialization	Air Bleeding	ECU Reset	Clutch Padal Adapt(M/T)	Fuel Efficiency Check Mode(While Inspecting)	Fuel Efficiency Driving Mode(After Inspecting)	Crank Angle Re Adapt(TEC Learn)	Reset TCM Adaption Value	Vibration Rate Sensor Adat	Sub System HS Combination Setting	Sub System ECB Combination Setting	Fault Continuation Time Check	Driver Seat SBR Setup	Passenger Seat SBR Setup	Idling RPM Check	Fuel Trim Check	DPF Recycle	Cranking RPM Check	Sub-system Combination Setup	Tire Size Setting	Steering Angle Sensor Calibration	Yaw G Sensor Calibration
SONIC	Body	Body control module																																																	
SONIC	Body	SRS Airbag																																																	
SONIC	Body	Instrument																																																	
N200/N300	N200	Engine																																																	
N200/N300	N200	Electronic Brake Control Module																																																	
N200/N300	N200	SRS Airbag																																																	
N200/N300	N300	Engine																																																	
N200/N300	N300	Electronic Brake Control Module																																																	
N200/N300	N300	SRS Airbag																																																	
Orlando	16 PIN	Engine																																																	
Orlando	16 PIN	Transmission																																																	
Orlando	16 PIN	Fuel Injector Control Module																																																	
Orlando	16 PIN	Electronic Brake Control Module																																																	
Orlando	16 PIN	Parking Brake Control Module																																																	
Orlando	16 PIN	Multi-Axis Acceleration Sensor Module																																																	
Orlando	16 PIN	Power Steering Control Module																																																	
Orlando	16 PIN	Steering Wheel Angle Sensor Module																																																	
Orlando	16 PIN	Body Control Module																																																	
Orlando	16 PIN	SDM(SRS Airbag)																																																	
Orlando	16 PIN	Instrument Cluster																																																	
Orlando	16 PIN	Trailer Interface Control Module																																																	
Orlando	16 PIN	Radio																																																	
Colorado/Colorado7	Engine	2.5L LVN Auto																																																	
Colorado/Colorado7	Engine	2.5L LVN Manual																																																	
Colorado/Colorado7	Engine	2.8L Diesel(LWH)																																																	
Colorado/Colorado7	Transmission	Auto transmission																																																	
Colorado/Colorado7	Chassis	EBCM(Electronic brake control module)																																																	
Colorado/Colorado7	Chassis	Transfer case module																																																	
Colorado/Colorado7	Chassis	Multi-Axis acceleration sensor module																																																	
Colorado/Colorado7	Chassis	Steering wheel angle sensor module																																																	
Colorado/Colorado7	Body	Immobilizer																																																	
Colorado/Colorado7	Body	SDM(Inflatable restraint sensing and diagnostic module)																																																	
Colorado/Colorado7	Body	2.5L LVN Body control module																																																	
Colorado/Colorado7	Body	BCM(Body control module)																																																	
Colorado/Colorado7	Body	IPC(Instrument cluster)																																																	

Vehicle	System 1	System 2	Open/Closed Loop Check	Hydraulic System Test	TCC Solenoid Adjustment	PCS Current Adjustment	Shift Gear Command	Manual Control	Gear Tension	Rank Information Program	TPMS ID Learn Mode	TPM Tire Type Setting	TPM Tire Pressure Unit Setting	Return to the Motor Home Position	Brake Adapt	SDM Primary Key in BCM	Reset Learned Value	Oil Remaining Life	ISU Key Coding	Immobilizer Learning	Rank Information Program	Wheel Circumference	Correction Factor Fuel Reset	Vheicle Variant Coding	Injector IQA Coding	Correction Factor Fuel Reset	EGR Cooler Reset	ECM Replace	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	RPM control	Injector cutoff test	Program transponder key	Erase transponder key	Reset service interval	Erase remote keys	Program remote key	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Steering angle sensor calibration	Learn Functions	Reset Function	HO2S Heater learn	Automated Brake Bleed	Fuel Composition Reset	Fuel Rail Pressure Sensor or Fuel Rail Learn
MAGNUS	POWERTRAIN	2.0 SOHC																																															
MAGNUS	POWERTRAIN	2.0 DOHC																																															
MAGNUS	POWERTRAIN	2.0 L6																																															
MAGNUS	POWERTRAIN	2.5 L6																																															
MAGNUS	POWERTRAIN	AUTO T/M																																															
MAGNUS	BODY	AIR BAG																																															
MAGNUS	BODY	ISU																																															
MAGNUS	CHASSIS	ABS																																															
MAGNUS	CHASSIS	SPSS DELPHI																																															
MAGNUS	CHASSIS	SPSS MANDO(L6)																																															
MATIZ/SPARK(M100)	POWERTRAIN	0.8S EOBD																																															
MATIZ/SPARK(M100)	POWERTRAIN	1.0S EOBD																																															
MATIZ/SPARK(M100)	BODY	AIR BAG																																															
MATIZ/SPARK(M100)	CHASSIS	ABS																																															
MATIZ/SPARK(M200)	POWERTRAIN	0.8S(EURO-II and ECE83)																																															
MATIZ/SPARK(M200)	POWERTRAIN	0.8S(EURO-III and IV or w/EOBD)																																															
MATIZ/SPARK(M200)	POWERTRAIN	1.0S(EURO-II and ECE83)																																															
MATIZ/SPARK(M200)	POWERTRAIN	1.0S(EURO-III and IV or w/EOBD)																																															
MATIZ/SPARK(M200)	POWERTRAIN	AUTO T/M																																															
MATIZ/SPARK(M200)	BODY	AIR BAG																																															
MATIZ/SPARK(M200)	CHASSIS	ABS																																															
SPARK(M300)	POWERTRAIN	Engine control unit(1.0L LEB)																																															
SPARK(M300)	POWERTRAIN	Engine control unit(1.0L LMT)																						V																										
SPARK(M300)	POWERTRAIN	ENGINE																																															
SPARK(M300)	POWERTRAIN	ENGINE LPG																																															
SPARK(M300)	POWERTRAIN	TCM																																															
SPARK(M300)	Chassis	EBCM(Electronic Brake Control Module)																																															
SPARK(M300)	Chassis	Steering wheel angle sensor module																																															
SPARK(M300)	Chassis	Multi axis acceleration sensor module																																															
SPARK(M300)	BODY	SDM																																															
SPARK(M300)	BODY	IPC																																															
SPARK(M300)	BODY	Keyless Entry																																															
LEZZO/TACUMA	POWERTRAIN 05	1.6 DOHC																																															
LEZZO/TACUMA	POWERTRAIN 05	1.8 DOHC																																															
LEZZO/TACUMA	POWERTRAIN 05	2.0 DOHC																																															
LEZZO/TACUMA	POWERTRAIN 05	AUTO T/M																																															
LEZZO/TACUMA	POWERTRAIN 06	1.6 DOHC																																															
LEZZO/TACUMA	POWERTRAIN 06	1.8 DOHC																																															

Vehicle	System 1	System 2	Open/Closed Loop Check	Hydraulic System Test	TCC Solenoid Adjustment	PCS Current Adjustment	Shift Gear Command	Manual Control	Gear Tension	Rank Information Program	TPMS ID Learn Mode	TPM Tire Type Setting	TPM Tire Pressure Unit Setting	Return to the Motor Home Position	Brake Adapt	SDM Primary Key in BCM	Reset Learned Value	Oil Remaining Life	ISU Key Coding	Immobilizer Learning	Rank Information Program	Wheel Circumference	Correction Factor Fuel Reset	Vheicle Variant Coding	Injector IQA Coding	Correction Factor Fuel Reset	EGR Cooler Reset	ECM Replace	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	RPM control	Injector cutoff test	Program transponder key	Erase transponder key	Reset service interval	Erase remote keys	Program remote key	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Steering angle sensor calibration	Learn Functions	Reset Function	HO2S Heater learn	Automated Brake Bleed	Fuel Composition Reset	Fuel Rail Pressure Sensor or Fuel Rail Learn
LEZZO/TACUMA	POWERTRAIN 06	2.0 DOHC																																															
LEZZO/TACUMA	POWERTRAIN 06	AUTO T/M																																															
LEZZO/TACUMA	BODY	AIR BAG																																															
LEZZO/TACUMA	CHASSIS	ABS																																															
LEZZO/TACUMA	POWERTRAIN 05	1.2 SOHC																																															
LEZZO/TACUMA	POWERTRAIN 05	1.4 SOHC																																															
LEZZO/TACUMA	POWERTRAIN 05	1.4 DOHC																																															
LEZZO/TACUMA	POWERTRAIN 05	1.5 SOHC																																															
LEZZO/TACUMA	POWERTRAIN 05	1.6 DOHC																																															
LEZZO/TACUMA	POWERTRAIN 05	AUTO T/M																																															
LEZZO/TACUMA	POWERTRAIN 06	1.2 SOHC																																															
LEZZO/TACUMA	POWERTRAIN 06	1.4 SOHC																																															
LEZZO/TACUMA	POWERTRAIN 06	1.4 DOHC																																															
LEZZO/TACUMA	POWERTRAIN 06	1.5 SOHC																																															
LEZZO/TACUMA	POWERTRAIN 06	1.6 DOHC																																															
LEZZO/TACUMA	POWERTRAIN 06	AUTO T/M																																															
LEZZO/TACUMA	BODY	AIR BAG																																															
LEZZO/TACUMA	CHASSIS	ABS																																															
KALOS/AVEO	POWERTRAIN 05	1.2 SOHC																																															
KALOS/AVEO	POWERTRAIN 05	1.4 SOHC																																															
KALOS/AVEO	POWERTRAIN 05	1.4 DOHC																																															
KALOS/AVEO	POWERTRAIN 05	1.5 SOHC																																															
KALOS/AVEO	POWERTRAIN 05	1.6 DOHC																																															
KALOS/AVEO	POWERTRAIN 05	AUTO T/M																																															
KALOS/AVEO	POWERTRAIN 06	1.2 SOHC																																															
KALOS/AVEO	POWERTRAIN 06	1.4 SOHC																																															
KALOS/AVEO	POWERTRAIN 06	1.4 DOHC																																															
KALOS/AVEO	POWERTRAIN 06	1.5 SOHC																																															
KALOS/AVEO	POWERTRAIN 06	1.6 DOHC																																															
KALOS/AVEO	POWERTRAIN 06	AUTO T/M																																															
KALOS/AVEO	BODY	AIR BAG																																															
KALOS/AVEO	CHASSIS	ABS																																															
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.4 DOHC																																															
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.5 DOHC																																															
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.6 DOHC																																															
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	1.8 DOHC																																															
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 05	AUTO T/M																																															
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.4 DOHC																																															

Vehicle	System 1	System 2	Open/Closed Loop Check	Hydraulic System Test	TCC Solenoid Adjustment	PCS Current Adjustment	Shift Gear Command	Manual Control	Gear Tension	Rank Information Program	TPMS ID Learn Mode	TPM Tire Type Setting	TPM Tire Pressure Unit Setting	Return to the Motor Home Position	Brake Adapt	SDM Primary Key in BCM	Reset Learned Value	Oil Remaining Life	ISU Key Coding	Immobilizer Learning	Rank Information Program	Wheel Circumference	Correction Factor Fuel Reset	Vheicle Variant Coding	Injector IQA Coding	Correction Factor Fuel Reset	EGR Cooler Reset	ECM Replace	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	RPM control	Injector cutoff test	Program transponder key	Erase transponder key	Reset service interval	Erase remote keys	Program remote key	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Steering angle sensor calibration	Learn Functions	Reset Function	HO2S Heater learn	Automated Brake Bleed	Fuel Composition Reset	Fuel Rail Pressure Sensor or Fuel Rail Learn
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.5 DOHC																																															
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.6 DOHC																																															
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	1.8 DOHC																																															
NUBIRA/LACETTI/OPTRA(J200)	POWERTRAIN 06	AUTO T/M																																															
NUBIRA/LACETTI/OPTRA(J200)	BODY	AIR BAG																																															
NUBIRA/LACETTI/OPTRA(J200)	CHASSIS	ABS																																															
NUBIRA/LACETTI/OPTRA(J200)	CHASSIS	SSPS																																															
AVEO(T250)	POWERTRAIN	1.2 SOHC																																															
AVEO(T250)	POWERTRAIN	1.4 SOHC																																															
AVEO(T250)	POWERTRAIN	1.4 DOHC																																															
AVEO(T250)	POWERTRAIN	1.5 SOHC																																															
AVEO(T250)	POWERTRAIN	1.6 DOHC																																															
AVEO(T250)	POWERTRAIN	AUTO T/M																																															
AVEO(T250)	BODY	AIR BAG																																															
AVEO(T250)	CHASSIS	ABS																																															
EPICA/TOSCA	POWERTRAIN	2.0 DOHC																																															
EPICA/TOSCA	POWERTRAIN	2.5 DOHC																																															
EPICA/TOSCA	POWERTRAIN	Diesel																			V	V	V	V	V		V	V																						
EPICA/TOSCA	POWERTRAIN	A/TAisin 5																																															
EPICA/TOSCA	POWERTRAIN	A/TGF6																																															
EPICA/TOSCA	BODY	AIR BAG																																															
EPICA/TOSCA	BODY	ISU																	V																														
EPICA/TOSCA	CHASSIS	ABS																																															
EPICA/TOSCA	CHASSIS	SSPS																																															
CAPTIVA	POWERTRAIN	ECM(DIESEL)																			V	V	V	V	V		V	V																						
CAPTIVA	POWERTRAIN	ECM(2.4D)																		V																													
CAPTIVA	POWERTRAIN	ECM(3.2D)															V	V		V																													
CAPTIVA	POWERTRAIN	TCM															V																																
CAPTIVA	BODY	SDM														V																																	
CAPTIVA	BODY	IPC																																															
CAPTIVA	BODY	BCM														V																																	
CAPTIVA	BODY	VTD																																															
CAPTIVA	BODY	RFA									V	V	V																																				
CAPTIVA	CHASSIS	EBCM(ABS/ESC)																																															
CAPTIVA	CHASSIS	TCCM								V																																							
Captiva 5/7	Powertrain	Engine control module(2.2L LNQ)																																															
Captiva 5/7	Powertrain	Engine control module(2.4L LE5)																																															
Captiva 5/7	Powertrain	Engine control module(2.4L LE9)																																											V		V		

Vehicle	System 1	System 2	Open/Closed Loop Check	Hydraulic System Test	TCC Solenoid Adjustment	PCS Current Adjustment	Shift Gear Command	Manual Control	Gear Tension	Rank Information Program	TPMS ID Learn Mode	TPM Tire Type Setting	TPM Tire Pressure Unit Setting	Return to the Motor Home Position	Brake Adapt	SDM Primary Key in BCM	Reset Learned Value	Oil Remaining Life	ISU Key Coding	Immobilizer Learning	Rank Information Program	Wheel Circumference	Correction Factor Fuel Reset	Vheicle Variant Coding	Injector IQA Coding	Correction Factor Fuel Reset	EGR Cooler Reset	ECM Replace	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	RPM control	Injector cutoff test	Program transponder key	Erase transponder key	Reset service interval	Erase remote keys	Program remote key	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Steering angle sensor calibration	Learn Functions	Reset Function	HO2S Heater learn	Automated Brake Bleed	Fuel Composition Reset	Fuel Rail Pressure Sensor or Fuel Rail Learn
Captiva 5/7	Powertrain	Engine control module(3.0L LF1)																																															
Captiva 5/7	Powertrain	Transmission control module																																															
Captiva 5/7	Powertrain	Fuel pump control module																																															
Captiva 5/7	Chassis	Electronic brake control module																																															
Captiva 5/7	Chassis	Parking brake control module																																															
Captiva 5/7	Chassis	Rear differential clutch control module																																															
Captiva 5/7	Body	Body control module																																															
Captiva 5/7	Body	Inflatable restraint sensing and diagnostic module																																															
Captiva 5/7	Body	Instrument panel cluster																																															
Captiva 5/7	Body	HVAC control module																																															
Captiva 5/7	Body	Remote control door lock receiver																																															
Captiva 5/7	Body	Theft deterrent module																																															
Captiva 5/7	Body	Parking assist control module																																															
Captiva 5/7	Information	Radio																																															
CRUZE	POWERTRAIN	Engine control module(1.4L LUJ))																																															
CRUZE	POWERTRAIN	Engine control module(2.0L LNP)																																															
CRUZE	POWERTRAIN	Engine Control Module-Diesel																																															
CRUZE	POWERTRAIN	Engine Control Module																																															
CRUZE	POWERTRAIN	Fuel Pump Control Module																																															
CRUZE	POWERTRAIN	Transmission Control Module																																															
CRUZE	CHASSIS	Electronic Brake Control Module With TCC																																															
CRUZE	CHASSIS	Electronic Brake Control Module Without TCC																																															
CRUZE	CHASSIS	Electric Power Steering Control Module																																															
CRUZE	CHASSIS	Steering wheel angle sensor module																																															
CRUZE	BODY	Body Control Module																																															
CRUZE	BODY	SDM(SRS Airbag)																																															
CRUZE	BODY	Passenger Presence Module																																															
CRUZE	BODY	Instrument Panel Cluster																																															
CRUZE	BODY	Heating Ventilating and Air Conditioning-Other																																															
CRUZE	BODY	Heating Ventilating and Air Conditioning-Manual																																															
CRUZE	BODY	Front Seat Heating Control Module																																															
CRUZE	BODY	Parking Assist Control Module																																															
CRUZE	BODY	Passive Entry Passive Start																																															
CRUZE	BODY	Steering Column Lock Control Module																																															
CRUZE	BODY	Multi axis acceleration sensor module																																															
CRUZE	Infotainment	Radio																																															
CRUZE	Infotainment	Telematics Communication Interface Control Module																																															
Lacetti Premiere	Powertrain	Diesel																				V		V	V	V	V																							

Vehicle	System 1	System 2	Open/Closed Loop Check	Hydraulic System Test	TCC Solenoid Adjustment	PCS Current Adjustment	Shift Gear Command	Manual Control	Gear Tension	Rank Information Program	TPMS ID Learn Mode	TPM Tire Type Setting	TPM Tire Pressure Unit Setting	Return to the Motor Home Position	Brake Adapt	SDM Primary Key in BCM	Reset Learned Value	Oil Remaining Life	ISU Key Coding	Immobilizer Learning	Rank Information Program	Wheel Circumference	Correction Factor Fuel Reset	Vheicle Variant Coding	Injector IQA Coding	Correction Factor Fuel Reset	EGR Cooler Reset	ECM Replace	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	RPM control	Injector cutoff test	Program transponder key	Erase transponder key	Reset service interval	Erase remote keys	Program remote key	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Steering angle sensor calibration	Learn Functions	Reset Function	HO2S Heater learn	Automated Brake Bleed	Fuel Composition Reset	Fuel Rail Pressure Sensor or Fuel Rail Learn
Lacetti Premiere	Powertrain	FAM1																																															
Lacetti Premiere	Powertrain	FPCM																																															
Lacetti Premiere	Powertrain	GF6 TCM																																															
Lacetti Premiere	Chassis	EBCM																																															
Lacetti Premiere	Chassis	EPS																																															
Lacetti Premiere	Body	BCM													V	V																																	
Lacetti Premiere	Body	SDM																																															
Lacetti Premiere	Body	IPC																																															
Lacetti Premiere	Body	HVAC																																															
Lacetti Premiere	Body	HVSM-F																																															
Lacetti Premiere	Body	PAM																																															
Lacetti Premiere	Body	PEPS																																															
Lacetti Premiere	Body	ESCL																																															
Lacetti Premiere	Infortainment	IRC																																															
Lacetti Premiere	Infortainment	PDIM																																															
NABIRA(Zafira-A)	Engine	Z 18 XE																										V	V	V	V	V	V																
NABIRA(Zafira-A)	Engine	Z 22 SE																												V	V								V	V	V								
NABIRA(Zafira-A)	Transmission	AF 13-II/17/20/22																																															
NABIRA(Zafira-A)	Transmission	AF 13-II/17/20/22 CAN																																															
NABIRA(Zafira-A)	Chassis	ABS 5.3/5.4 +TC																																															
NABIRA(Zafira-A)	Chassis	ESP																																								V							
NABIRA(Zafira-A)	Chassis	Electronic Power Steering																																															
NABIRA(Zafira-A)	Body	Immobiliser																																	V	V													
NABIRA(Zafira-A)	Body	SRS Airbag																																															
NABIRA(Zafira-A)	Body	Instrument																																			V												
NABIRA(Zafira-A)	Body	Engine Cooling Module																																															
NABIRA(Zafira-A)	Body	Add On Heater																																															
NABIRA(Zafira-A)	Body	Electronic Climate Control																																															
NABIRA(Zafira-A)	Body	Central Door Lock																										V	V									V	V										
NABIRA(Zafira-A)	Infortainment System	Trip Info Display																																															
NABIRA(Zafira-A)	Infortainment System	Multi Info Display																																															
SAIL	Powertrain	1.4L LCU																																									V	V					
SAIL	Powertrain	Transmission																																															
SAIL	Body	AIR BAG																																															
SAIL	Chassis	ABS																																															
SONIC	Powertrain	Engine 1.6L LDE																																											V				
SONIC	Chassis	Electronic brake control module																																												V			
SONIC	Body	Immobiliser																																															

Vehicle	System 1	System 2	Open/Closed Loop Check	Hydraulic System Test	TCC Solenoid Adjustment	PCS Current Adjustment	Shift Gear Command	Manual Control	Gear Tension	Rank Information Program	TPMS ID Learn Mode	TPM Tire Type Setting	TPM Tire Pressure Unit Setting	Return to the Motor Home Position	Brake Adapt	SDM Primary Key in BCM	Reset Learned Value	Oil Remaining Life	ISU Key Coding	Immobilizer Learning	Rank Information Program	Wheel Circumference	Correction Factor Fuel Reset	Vheicle Variant Coding	Injector IQA Coding	Correction Factor Fuel Reset	EGR Cooler Reset	ECM Replace	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	RPM control	Injector cutoff test	Program transponder key	Erase transponder key	Reset service interval	Erase remote keys	Program remote key	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Steering angle sensor calibration	Learn Functions	Reset Function	HO2S Heater learn	Automated Brake Bleed	Fuel Composition Reset	Fuel Rail Pressure Sensor or Fuel Rail Learn
SONIC	Body	Body control module																																															
SONIC	Body	SRS Airbag																																															
SONIC	Body	Instrument																																															
N200/N300	N200	Engine																																															
N200/N300	N200	Electronic Brake Control Module																																															
N200/N300	N200	SRS Airbag																																															
N200/N300	N300	Engine																																															
N200/N300	N300	Electronic Brake Control Module																																															
N200/N300	N300	SRS Airbag																																															
Orlando	16 PIN	Engine																																															
Orlando	16 PIN	Transmission																																															
Orlando	16 PIN	Fuel Injector Control Module																																															
Orlando	16 PIN	Electronic Brake Control Module																																															
Orlando	16 PIN	Parking Brake Control Module																																															
Orlando	16 PIN	Multi-Axis Acceleration Sensor Module																																															
Orlando	16 PIN	Power Steering Control Module																																															
Orlando	16 PIN	Steering Wheel Angle Sensor Module																																															
Orlando	16 PIN	Body Control Module																																															
Orlando	16 PIN	SDM(SRS Airbag)																																															
Orlando	16 PIN	Instrument Cluster																																															
Orlando	16 PIN	Trailer Interface Control Module																																															
Orlando	16 PIN	Radio																																															
Colorado/Colorado7	Engine	2.5L LVN Auto																																															V
Colorado/Colorado7	Engine	2.5L LVN Manual																																															V
Colorado/Colorado7	Engine	2.8L Diesel(LWH)																																															
Colorado/Colorado7	Transmission	Auto transmission																																															
Colorado/Colorado7	Chassis	EBCM(Electronic brake control module)																																															
Colorado/Colorado7	Chassis	Transfer case module																																															
Colorado/Colorado7	Chassis	Multi-Axis acceleration sensor module																																															
Colorado/Colorado7	Chassis	Steering wheel angle sensor module																																															
Colorado/Colorado7	Body	Immobilizer																																															
Colorado/Colorado7	Body	SDM(Inflatable restraint sensing and diagnostic module)																																															
Colorado/Colorado7	Body	2.5L LVN Body control module																																															
Colorado/Colorado7	Body	BCM(Body control module)																																															
Colorado/Colorado7	Body	IPC(Instrument cluster)																																															

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
General(CAN Bus)	ALL	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
General(CAN Bus)	ALL	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
General(CAN Bus)	ALL	ACC (Adaptive Cruise Control)	V			V																																									
General(CAN Bus)	ALL	ADCM (Adaptive Damper Control Module)	V			V																																									
General(CAN Bus)	ALL	AFLS (Adaptive Front Light System)	V			V																																									
General(CAN Bus)	ALL	AHBM (Automatic High Beam)	V			V																																									
General(CAN Bus)	ALL	AMP (Audio)	V	V		V																																									
General(CAN Bus)	ALL	BCM (Body Control Module)	V			V																																									
General(CAN Bus)	ALL	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																									
General(CAN Bus)	ALL	FFCM (Front Facing Camera Module)	V	V	V	V																																									
General(CAN Bus)	ALL	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																									
General(CAN Bus)	ALL	CGW (Central Gateway)	V	V	V	V																																									
General(CAN Bus)	ALL	DDM (Drivers Door Module)	V	V	V	V																																									
General(CAN Bus)	ALL	DTCM (Drive Train Control Module)	V			V																																									
General(CAN Bus)	ALL	EDM (Electronic Damper Module)	V			V																																									
General(CAN Bus)	ALL	EOM (Electric Overhead Module)	V	V	V	V																																									
General(CAN Bus)	ALL	EPB (Electrical Parking Brake)	V	V		V																																									
General(CAN Bus)	ALL	EPS (Electric Power Steering)	V			V																																									
General(CAN Bus)	ALL	ESM (Electronic Shifter Module)	V			V																																									
General(CAN Bus)	ALL	HFM (Hands Free Module)	V	V	V	V																																									
General(CAN Bus)	ALL	HSM (Heated Seat Module)	V			V																																									
General(CAN Bus)	ALL	HVAC (Heat Vent A/C)	V	V	V	V																																									
General(CAN Bus)	ALL	ICS (Integrated Center Stack)	V			V																																									
General(CAN Bus)	ALL	IPC (Instrument Panel Cluster)	V			V																																									
General(CAN Bus)	ALL	ITM (Intrusion)	V			V																																									
General(CAN Bus)	ALL	LBSS (Left Blind Spot Sensor)	V			V																																									
General(CAN Bus)	ALL	LRSM (Light Rain Sensor Module)	V			V																																									
General(CAN Bus)	ALL	MSMD (Memory Seet Module)	V	V	V	V																																									
General(CAN Bus)	ALL	OCM (Occupant Classification Module)	V			V																																									
General(CAN Bus)	ALL	ORC (Occupant Restraint Control)	V	V		V																																									
General(CAN Bus)	ALL	PDM (Passenger Door Module)	V	V	V	V																																									
General(CAN Bus)	ALL	PLM (Power Liftgate Module)	V			V																																									
General(CAN Bus)	ALL	PTS (Park Assist Module)	V			V																																									
General(CAN Bus)	ALL	RADIO (Radio)	V	V		V																																									
General(CAN Bus)	ALL	RBSS (Right Blind Spot Sensor)	V			V																																									
General(CAN Bus)	ALL	RFH (Radio Frequency Hub)	V			V																																									
General(CAN Bus)	ALL	SAS (Steering Angle Sensor)	V	V	V	V																																									
General(CAN Bus)	ALL	SCM (Steering Column Module)	V			V																																									
General(CAN Bus)	ALL	SDAR (Satellite Radio)	V			V																																									
General(CAN Bus)	ALL	SUNR (Sunroof Module)	V			V																																									
General(CAN Bus)	ALL	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
General(CAN Bus)	ALL	TGW (Telematics Gateway)	V			V																																									

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
General(CAN Bus)	ALL	TPM (Tire Pressure Monitor)	V			V																																										
General(CAN Bus)	ALL	VES3 (Vidio Entertainment System 3)	V			V																																										
General(CAN Bus)	ALL	WCM(Wireless Control Modules)	V	V	V	V																																										
200	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
200	2016	ABS (Anti Lock Brake System)	V			V																																										
200	2016	ACC (Adaptive Cruise Control)	V			V																																										
200	2016	AMP (Audio)	V			V																																										
200	2016	BCM (Body Control Module)	V			V																																										
200	2016	FFCM (Front Facing Camera Module)	V	V	V	V																																										
200	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
200	2016	CGW (Central Gateway)	V			V																																										
200	2016	DDM (Drivers Door Module)	V			V																																										
200	2016	DTCM (Drive Train Control Module)	V			V																																										
200	2016	EPB (Electrical Parking Brake)	V	V		V																																										
200	2016	EPS (Electric Power Steering)	V			V																																										
200	2016	ESM (Electronic Shifter Module)	V			V																																										
200	2016	HVAC (Heat Vent A/C)	V			V																																										
200	2016	ICS (Integrated Center Stack)	V			V																																										
200	2016	IPC (Instrument Panel Cluster)	V			V																																										
200	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
200	2016	MSMD (Memory Seet Module)	V			V																																										
200	2016	OCM (Occupant Classification Module)	V			V																																										
200	2016	ORC (Occupant Restraint Control)	V			V																																										
200	2016	PDM (Passenger Door Module)	V			V																																										
200	2016	RADIO (Radio)	V			V																																										
200	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
200	2016	RFH (Radio Frequency Hub)	V			V																																										
200	2016	SCM (Steering Column Module)	V			V																																										
200	2016	TCM (Transmission Control Module)	V			V																																										
200	2016	WCM(Wireless Control Modules)	V			V																																										
200	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
200	2015	ABS (Anti Lock Brake System)	V			V																																										
200	2015	ACC (Adaptive Cruise Control)	V			V																																										
200	2015	AMP (Audio)	V			V																																										
200	2015	BCM (Body Control Module)	V			V																																										
200	2015	FFCM (Front Facing Camera Module)	V	V	V	V																																										
200	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
200	2015	CGW (Central Gateway)	V			V																																										
200	2015	DDM (Drivers Door Module)	V			V																																										
200	2015	DTCM (Drive Train Control Module)	V			V																																										
200	2015	EPB (Electrical Parking Brake)	V	V		V																																										
200	2015	EPS (Electric Power Steering)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
200	2015	ESM (Electronic Shifter Module)	V			V																																										
200	2015	HVAC (Heat Vent A/C)	V			V																																										
200	2015	ICS (Integrated Center Stack)	V			V																																										
200	2015	IPC (Instrument Panel Cluster)	V			V																																										
200	2015	LBSS (Left Blind Spot Sensor)	V			V																																										
200	2015	MSMD (Memory Seet Module)	V			V																																										
200	2015	OCM (Occupant Classification Module)	V			V																																										
200	2015	ORC (Occupant Restraint Control)	V			V																																										
200	2015	PDM (Passenger Door Module)	V			V																																										
200	2015	RADIO (Radio)	V			V																																										
200	2015	RBSS (Right Blind Spot Sensor)	V			V																																										
200	2015	RFH (Radio Frequency Hub)	V			V																																										
200	2015	SCM (Steering Column Module)	V			V																																										
200	2015	TCM (Transmission Control Module)	V			V																																										
200	2015	WCM(Wireless Control Modules)	V			V																																										
200	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
200	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
200	2014	AMP (Audio)	V	V		V																																										
200	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
200	2014	DDM (Drivers Door Module)	V	V	V	V																																										
200	2014	HFM (Hands Free Module)	V	V	V	V																																										
200	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
200	2014	ORC (Occupant Restraint Control)	V	V		V																																										
200	2014	PDM (Passenger Door Module)	V	V	V	V																																										
200	2014	RADIO (Radio)	V	V		V																																										
200	2014	SAS (Steering Angle Sensor)	V	V	V	V																																										
200	2014	CGW (Central Gateway)	V	V	V	V																																										
200	2014	WCM(Wireless Control Modules)	V	V	V	V																																										
200	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
200	2013	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
200	2013	AMP (Audio)	V	V		V																																										
200	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
200	2013	DDM (Drivers Door Module)	V	V	V	V																																										
200	2013	HFM (Hands Free Module)	V	V	V	V																																										
200	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
200	2013	ORC (Occupant Restraint Control)	V	V		V																																										
200	2013	PDM (Passenger Door Module)	V	V	V	V																																										
200	2013	RADIO (Radio)	V	V		V																																										
200	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
200	2013	CGW (Central Gateway)	V	V	V	V																																										
200	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
200	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
200	2012	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
200	2012	AMP (Audio)	V	V		V																																										
200	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
200	2012	DDM (Drivers Door Module)	V	V	V	V																																										
200	2012	HFM (Hands Free Module)	V	V	V	V																																										
200	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
200	2012	ORC (Occupant Restraint Control)	V	V		V																																										
200	2012	PDM (Passenger Door Module)	V	V	V	V																																										
200	2012	RADIO (Radio)	V	V		V																																										
200	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
200	2012	CGW (Central Gateway)	V	V	V	V																																										
200	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
200	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
200	2011	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
200	2011	AMP (Audio)	V	V		V																																										
200	2011	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
200	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
200	2011	DDM (Drivers Door Module)	V	V	V	V																																										
200	2011	ESM (Electronic Shifter Module)	V			V																																										
200	2011	HFM (Hands Free Module)	V	V	V	V																																										
200	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
200	2011	ITM (Intrusion)	V			V																																										
200	2011	ORC (Occupant Restraint Control)	V	V		V																																										
200	2011	PDM (Passenger Door Module)	V	V	V	V																																										
200	2011	RADIO (Radio)	V	V		V																																										
200	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
200	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
200	2011	CGW (Central Gateway)	V	V	V	V																																										
200	2011	VES3 (Vidio Entertainment System 3)	V			V																																										
200	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
200	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
200	2010	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
200	2010	AMP (Audio)	V	V		V																																										
200	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
200	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
200	2010	DDM (Drivers Door Module)	V	V	V	V																																										
200	2010	HFM (Hands Free Module)	V	V	V	V																																										
200	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
200	2010	ITM (Intrusion)	V			V																																										
200	2010	ORC (Occupant Restraint Control)	V	V		V																																										
200	2010	PDM (Passenger Door Module)	V	V	V	V																																										
200	2010	RADIO (Radio)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
200	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
200	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
200	2010	CGW (Central Gateway)	V	V	V	V																																										
200	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
200	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
200	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
200	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
200	2009	AMP (Audio)	V	V		V																																										
200	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
200	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
200	2009	DDM (Drivers Door Module)	V	V	V	V																																										
200	2009	HFM (Hands Free Module)	V	V	V	V																																										
200	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
200	2009	ITM (Intrusion)	V			V																																										
200	2009	ORC (Occupant Restraint Control)	V	V		V																																										
200	2009	PDM (Passenger Door Module)	V	V	V	V																																										
200	2009	RADIO (Radio)	V	V		V																																										
200	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
200	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
200	2009	CGW (Central Gateway)	V	V	V	V																																										
200	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
200	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
200	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
200	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
200	2008	AMP (Audio)	V	V		V																																										
200	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
200	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
200	2008	DDM (Drivers Door Module)	V	V	V	V																																										
200	2008	HFM (Hands Free Module)	V	V	V	V																																										
200	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
200	2008	ITM (Intrusion)	V			V																																										
200	2008	ORC (Occupant Restraint Control)	V	V		V																																										
200	2008	PDM (Passenger Door Module)	V	V	V	V																																										
200	2008	RADIO (Radio)	V	V		V																																										
200	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
200	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
200	2008	CGW (Central Gateway)	V	V	V	V																																										
200	2008	VES3 (Vidio Entertainment System 3)	V			V																																										
200	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
200	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
200	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
200	2007	AMP (Audio)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
200	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
200	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
200	2007	DDM (Drivers Door Module)	V	V	V	V																																										
200	2007	HFM (Hands Free Module)	V	V	V	V																																										
200	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
200	2007	ITM (Intrusion)	V			V																																										
200	2007	ORC (Occupant Restraint Control)	V	V		V																																										
200	2007	PDM (Passenger Door Module)	V	V	V	V																																										
200	2007	RADIO (Radio)	V	V		V																																										
200	2007	SAS (Steering Angle Sensor)	V	V	V	V																																										
200	2007	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
200	2007	CGW (Central Gateway)	V	V	V	V																																										
200	2007	VES3 (Vidio Entertainment System 3)	V			V																																										
200	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
300	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
300	2016	ABS (Anti Lock Brake System)	V			V																																										
300	2016	ACC (Adaptive Cruise Control)	V			V																																										
300	2016	ADCM (Adaptive Damper Control Module)	V			V																																										
300	2016	AFLS (Adaptive Front Light System)	V			V																																										
300	2016	AMP (Audio)	V			V																																										
300	2016	BCM (Body Control Module)	V			V																																										
300	2016	FFCM (Front Facing Camera Module)	V	V	V	V																																										
300	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
300	2016	CGW (Central Gateway)	V			V																																										
300	2016	DDM (Drivers Door Module)	V			V																																										
300	2016	DTCM (Drive Train Control Module)	V			V																																										
300	2016	EPS (Electric Power Steering)	V			V																																										
300	2016	ESM (Electronic Shifter Module)	V			V																																										
300	2016	HSM (Heated Seat Module)	V			V																																										
300	2016	HVAC (Heat Vent A/C)	V			V																																										
300	2016	ICS (Integrated Center Stack)	V			V																																										
300	2016	IPC (Instrument Panel Cluster)	V			V																																										
300	2016	ITM (Intrusion)	V			V																																										
300	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
300	2016	ORC (Occupant Restraint Control)	V			V																																										
300	2016	PDM (Passenger Door Module)	V			V																																										
300	2016	PTS (Park Assist Module)	V			V																																										
300	2016	RADIO (Radio)	V			V																																										
300	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
300	2016	RFH (Radio Frequency Hub)	V			V																																										
300	2016	SCM (Steering Column Module)	V			V																																										
300	2016	TCM (Transmission Control Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
300	2016	WCM(Wireless Control Modules)	V			V																																										
300	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
300	2015	ABS (Anti Lock Brake System)	V			V																																										
300	2015	ACC (Adaptive Cruise Control)	V			V																																										
300	2015	ADCM (Adaptive Damper Control Module)	V			V																																										
300	2015	AFLS (Adaptive Front Light System)	V			V																																										
300	2015	AMP (Audio)	V			V																																										
300	2015	BCM (Body Control Module)	V			V																																										
300	2015	FFCM (Front Facing Camera Module)	V	V	V	V																																										
300	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
300	2015	CGW (Central Gateway)	V			V																																										
300	2015	DDM (Drivers Door Module)	V			V																																										
300	2015	DTCM (Drive Train Control Module)	V			V																																										
300	2015	EPS (Electric Power Steering)	V			V																																										
300	2015	ESM (Electronic Shifter Module)	V			V																																										
300	2015	HSM (Heated Seat Module)	V			V																																										
300	2015	HVAC (Heat Vent A/C)	V			V																																										
300	2015	ICS (Integrated Center Stack)	V			V																																										
300	2015	IPC (Instrument Panel Cluster)	V			V																																										
300	2015	ITM (Intrusion)	V			V																																										
300	2015	LBSS (Left Blind Spot Sensor)	V			V																																										
300	2015	ORC (Occupant Restraint Control)	V			V																																										
300	2015	PDM (Passenger Door Module)	V			V																																										
300	2015	PTS (Park Assist Module)	V			V																																										
300	2015	RADIO (Radio)	V			V																																										
300	2015	RBSS (Right Blind Spot Sensor)	V			V																																										
300	2015	RFH (Radio Frequency Hub)	V			V																																										
300	2015	SCM (Steering Column Module)	V			V																																										
300	2015	TCM (Transmission Control Module)	V			V																																										
300	2015	WCM(Wireless Control Modules)	V			V																																										
300	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
300	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
300	2014	ACC (Adaptive Cruise Control)	V			V																																										
300	2014	AMP (Audio)	V	V		V																																										
300	2014	DDM (Drivers Door Module)	V	V	V	V																																										
300	2014	DTCM (Drive Train Control Module)	V			V																																										
300	2014	ESM (Electronic Shifter Module)	V			V																																										
300	2014	HFM (Hands Free Module)	V	V	V	V																																										
300	2014	HSM (Heated Seat Module)	V			V																																										
300	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
300	2014	ITM (Intrusion)	V			V																																										
300	2014	ORC (Occupant Restraint Control)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
300	2014	PDM (Passenger Door Module)	V	V	V	V																																										
300	2014	PTS (Park Assist Module)	V			V																																										
300	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
300	2014	TPM (Tire Pressure Monitor)	V			V																																										
300	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
300	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
300	2013	ACC (Adaptive Cruise Control)	V			V																																										
300	2013	AMP (Audio)	V	V		V																																										
300	2013	DDM (Drivers Door Module)	V	V	V	V																																										
300	2013	DTCM (Drive Train Control Module)	V			V																																										
300	2013	ESM (Electronic Shifter Module)	V			V																																										
300	2013	HFM (Hands Free Module)	V	V	V	V																																										
300	2013	HSM (Heated Seat Module)	V			V																																										
300	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
300	2013	ITM (Intrusion)	V			V																																										
300	2013	ORC (Occupant Restraint Control)	V	V		V																																										
300	2013	PDM (Passenger Door Module)	V	V	V	V																																										
300	2013	PTS (Park Assist Module)	V			V																																										
300	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
300	2013	TPM (Tire Pressure Monitor)	V			V																																										
300	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
300	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
300	2012	ACC (Adaptive Cruise Control)	V			V																																										
300	2012	AMP (Audio)	V	V		V																																										
300	2012	DDM (Drivers Door Module)	V	V	V	V																																										
300	2012	DTCM (Drive Train Control Module)	V			V																																										
300	2012	ESM (Electronic Shifter Module)	V			V																																										
300	2012	HFM (Hands Free Module)	V	V	V	V																																										
300	2012	HSM (Heated Seat Module)	V			V																																										
300	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
300	2012	ITM (Intrusion)	V			V																																										
300	2012	ORC (Occupant Restraint Control)	V	V		V																																										
300	2012	PDM (Passenger Door Module)	V	V	V	V																																										
300	2012	PTS (Park Assist Module)	V			V																																										
300	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
300	2012	TPM (Tire Pressure Monitor)	V			V																																										
300	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
300	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
300	2011	ACC (Adaptive Cruise Control)	V			V																																										
300	2011	AMP (Audio)	V	V		V																																										
300	2011	DDM (Drivers Door Module)	V	V	V	V																																										
300	2011	DTCM (Drive Train Control Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
300	2011	ESM (Electronic Shifter Module)	V			V																																										
300	2011	HFM (Hands Free Module)	V	V	V	V																																										
300	2011	HSM (Heated Seat Module)	V			V																																										
300	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
300	2011	ORC (Occupant Restraint Control)	V	V		V																																										
300	2011	PDM (Passenger Door Module)	V	V	V	V																																										
300	2011	PTS (Park Assist Module)	V			V																																										
300	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
300	2011	TPM (Tire Pressure Monitor)	V			V																																										
300	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
300	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
300	2010	ACC (Adaptive Cruise Control)	V			V																																										
300	2010	AHBM (Automatic High Beam)	V			V																																										
300	2010	AMP (Audio)	V	V		V																																										
300	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
300	2010	DDM (Drivers Door Module)	V	V	V	V																																										
300	2010	DTCM (Drive Train Control Module)	V			V																																										
300	2010	EOM (Electric Overhead Module)	V	V	V	V																																										
300	2010	ESM (Electronic Shifter Module)	V			V																																										
300	2010	HFM (Hands Free Module)	V	V	V	V																																										
300	2010	HSM (Heated Seat Module)	V			V																																										
300	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
300	2010	ITM (Intrusion)	V			V																																										
300	2010	LRSM (Light Rain Sensor Module)	V			V																																										
300	2010	MSMD (Memory Seet Module)	V	V	V	V																																										
300	2010	ORC (Occupant Restraint Control)	V	V		V																																										
300	2010	PDM (Passenger Door Module)	V	V	V	V																																										
300	2010	PTS (Park Assist Module)	V			V																																										
300	2010	RADIO (Radio)	V	V		V																																										
300	2010	SCM (Steering Column Module)	V			V																																										
300	2010	SUNR (Sunroof Module)	V			V																																										
300	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
300	2010	CGW (Central Gateway)	V	V	V	V																																										
300	2010	TPM (Tire Pressure Monitor)	V			V																																										
300	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
300	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
300	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
300	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
300	2009	ACC (Adaptive Cruise Control)	V			V																																										
300	2009	AHBM (Automatic High Beam)	V			V																																										
300	2009	AMP (Audio)	V	V		V																																										
300	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
300	2009	DDM (Drivers Door Module)	V	V	V	V																																										
300	2009	DTCM (Drive Train Control Module)	V			V																																										
300	2009	EOM (Electric Overhead Module)	V	V	V	V																																										
300	2009	ESM (Electronic Shifter Module)	V			V																																										
300	2009	HFM (Hands Free Module)	V	V	V	V																																										
300	2009	HSM (Heated Seat Module)	V			V																																										
300	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
300	2009	ITM (Intrusion)	V			V																																										
300	2009	LRSM (Light Rain Sensor Module)	V			V																																										
300	2009	MSMD (Memory Seet Module)	V	V	V	V																																										
300	2009	ORC (Occupant Restraint Control)	V	V		V																																										
300	2009	PDM (Passenger Door Module)	V	V	V	V																																										
300	2009	PTS (Park Assist Module)	V			V																																										
300	2009	RADIO (Radio)	V	V		V																																										
300	2009	SCM (Steering Column Module)	V			V																																										
300	2009	SUNR (Sunroof Module)	V			V																																										
300	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
300	2009	CGW (Central Gateway)	V	V	V	V																																										
300	2009	TPM (Tire Pressure Monitor)	V			V																																										
300	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
300	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
300	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
300	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
300	2008	ACC (Adaptive Cruise Control)	V			V																																										
300	2008	AHBM (Automatic High Beam)	V			V																																										
300	2008	AMP (Audio)	V	V		V																																										
300	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
300	2008	DDM (Drivers Door Module)	V	V	V	V																																										
300	2008	EOM (Electric Overhead Module)	V	V	V	V																																										
300	2008	ESM (Electronic Shifter Module)	V			V																																										
300	2008	HFM (Hands Free Module)	V	V	V	V																																										
300	2008	HSM (Heated Seat Module)	V			V																																										
300	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
300	2008	ITM (Intrusion)	V			V																																										
300	2008	LRSM (Light Rain Sensor Module)	V			V																																										
300	2008	MSMD (Memory Seet Module)	V	V	V	V																																										
300	2008	ORC (Occupant Restraint Control)	V	V		V																																										
300	2008	PDM (Passenger Door Module)	V	V	V	V																																										
300	2008	PTS (Park Assist Module)	V			V																																										
300	2008	RADIO (Radio)	V	V		V																																										
300	2008	SCM (Steering Column Module)	V			V																																										
300	2008	SUNR (Sunroof Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
300	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
300	2008	CGW (Central Gateway)	V	V	V	V																																									
300	2008	VES3 (Vidio Entertainment System 3)	V			V																																									
300	2008	WCM(Wireless Control Modules)	V	V	V	V																																									
300	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
300	2007	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
300	2007	ACC (Adaptive Cruise Control)	V			V																																									
300	2007	AHBM (Automatic High Beam)	V			V																																									
300	2007	AMP (Audio)	V	V		V																																									
300	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																									
300	2007	DDM (Drivers Door Module)	V	V	V	V																																									
300	2007	EOM (Electric Overhead Module)	V	V	V	V																																									
300	2007	ESM (Electronic Shifter Module)	V			V																																									
300	2007	HFM (Hands Free Module)	V	V	V	V																																									
300	2007	HSM (Heated Seat Module)	V			V																																									
300	2007	HVAC (Heat Vent A/C)	V	V	V	V																																									
300	2007	ITM (Intrusion)	V			V																																									
300	2007	LRSM (Light Rain Sensor Module)	V			V																																									
300	2007	MSMD (Memory Seet Module)	V	V	V	V																																									
300	2007	ORC (Occupant Restraint Control)	V	V		V																																									
300	2007	PDM (Passenger Door Module)	V	V	V	V																																									
300	2007	PTS (Park Assist Module)	V			V																																									
300	2007	RADIO (Radio)	V	V		V																																									
300	2007	SCM (Steering Column Module)	V			V																																									
300	2007	SDAR (Satellite Radio)	V			V																																									
300	2007	SUNR (Sunroof Module)	V			V																																									
300	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
300	2007	CGW (Central Gateway)	V	V	V	V																																									
300	2007	WCM(Wireless Control Modules)	V	V	V	V																																									
300	2006	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
300	2006	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
300	2006	AHBM (Automatic High Beam)	V			V																																									
300	2006	AMP (Audio)	V	V		V																																									
300	2006	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																									
300	2006	DDM (Drivers Door Module)	V	V	V	V																																									
300	2006	EOM (Electric Overhead Module)	V	V	V	V																																									
300	2006	ESM (Electronic Shifter Module)	V			V																																									
300	2006	HFM (Hands Free Module)	V	V	V	V																																									
300	2006	HSM (Heated Seat Module)	V			V																																									
300	2006	HVAC (Heat Vent A/C)	V	V	V	V																																									
300	2006	ITM (Intrusion)	V			V																																									
300	2006	LRSM (Light Rain Sensor Module)	V			V																																									

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
300	2006	MSMD (Memory Seet Module)	V	V	V	V																																										
300	2006	OCM (Occupant Classification Module)	V			V																																										
300	2006	ORC (Occupant Restraint Control)	V	V		V																																										
300	2006	PDM (Passenger Door Module)	V	V	V	V																																										
300	2006	PTS (Park Assist Module)	V			V																																										
300	2006	RADIO (Radio)	V	V		V																																										
300	2006	SCM (Steering Column Module)	V			V																																										
300	2006	SDAR (Satellite Radio)	V			V																																										
300	2006	SUNR (Sunroof Module)	V			V																																										
300	2006	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
300	2006	CGW (Central Gateway)	V	V	V	V																																										
300	2006	WCM(Wireless Control Modules)	V	V	V	V																																										
300	2005	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
300	2005	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
300	2005	AMP (Audio)	V	V		V																																										
300	2005	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
300	2005	DDM (Drivers Door Module)	V	V	V	V																																										
300	2005	EOM (Electric Overhead Module)	V	V	V	V																																										
300	2005	ESM (Electronic Shifter Module)	V			V																																										
300	2005	HFM (Hands Free Module)	V	V	V	V																																										
300	2005	HSM (Heated Seat Module)	V			V																																										
300	2005	HVAC (Heat Vent A/C)	V	V	V	V																																										
300	2005	LRSM (Light Rain Sensor Module)	V			V																																										
300	2005	MSMD (Memory Seet Module)	V	V	V	V																																										
300	2005	OCM (Occupant Classification Module)	V			V																																										
300	2005	ORC (Occupant Restraint Control)	V	V		V																																										
300	2005	PDM (Passenger Door Module)	V	V	V	V																																										
300	2005	PTS (Park Assist Module)	V			V																																										
300	2005	RADIO (Radio)	V	V		V																																										
300	2005	SCM (Steering Column Module)	V			V																																										
300	2005	SDAR (Satellite Radio)	V			V																																										
300	2005	SUNR (Sunroof Module)	V			V																																										
300	2005	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
300	2005	CGW (Central Gateway)	V	V	V	V																																										
300	2005	WCM(Wireless Control Modules)	V	V	V	V																																										
ASPEN	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
ASPEN	2009	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
ASPEN	2009	AMP (Audio)	V	V		V																																										
ASPEN	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
ASPEN	2009	DDM (Drivers Door Module)	V	V	V	V																																										
ASPEN	2009	EOM (Electric Overhead Module)	V	V	V	V																																										
ASPEN	2009	HFM (Hands Free Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
ASPEN	2009	HSM (Heated Seat Module)	V			V																																										
ASPEN	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
ASPEN	2009	MSMD (Memory Seet Module)	V	V	V	V																																										
ASPEN	2009	ORC (Occupant Restraint Control)	V	V		V																																										
ASPEN	2009	PDM (Passenger Door Module)	V	V	V	V																																										
ASPEN	2009	PLM (Power Liftgate Module)	V			V																																										
ASPEN	2009	PTS (Park Assist Module)	V			V																																										
ASPEN	2009	RADIO (Radio)	V	V		V																																										
ASPEN	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
ASPEN	2009	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
ASPEN	2009	CGW (Central Gateway)	V	V	V	V																																										
ASPEN	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
ASPEN	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
ASPEN	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
ASPEN	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
ASPEN	2008	AMP (Audio)	V	V		V																																										
ASPEN	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
ASPEN	2008	DDM (Drivers Door Module)	V	V	V	V																																										
ASPEN	2008	EOM (Electric Overhead Module)	V	V	V	V																																										
ASPEN	2008	HFM (Hands Free Module)	V	V	V	V																																										
ASPEN	2008	HSM (Heated Seat Module)	V			V																																										
ASPEN	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
ASPEN	2008	MSMD (Memory Seet Module)	V	V	V	V																																										
ASPEN	2008	ORC (Occupant Restraint Control)	V	V		V																																										
ASPEN	2008	PDM (Passenger Door Module)	V	V	V	V																																										
ASPEN	2008	PLM (Power Liftgate Module)	V			V																																										
ASPEN	2008	PTS (Park Assist Module)	V			V																																										
ASPEN	2008	RADIO (Radio)	V	V		V																																										
ASPEN	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
ASPEN	2008	CGW (Central Gateway)	V	V	V	V																																										
ASPEN	2008	VES3 (Vidio Entertainment System 3)	V			V																																										
ASPEN	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
ASPEN	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
ASPEN	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
ASPEN	2007	AMP (Audio)	V	V		V																																										
ASPEN	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
ASPEN	2007	DDM (Drivers Door Module)	V	V	V	V																																										
ASPEN	2007	EOM (Electric Overhead Module)	V	V	V	V																																										
ASPEN	2007	HFM (Hands Free Module)	V	V	V	V																																										
ASPEN	2007	HSM (Heated Seat Module)	V			V																																										
ASPEN	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
ASPEN	2007	MSMD (Memory Seet Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
ASPEN	2007	ORC (Occupant Restraint Control)	V	V		V																																										
ASPEN	2007	PDM (Passenger Door Module)	V	V	V	V																																										
ASPEN	2007	PLM (Power Liftgate Module)	V			V																																										
ASPEN	2007	PTS (Park Assist Module)	V			V																																										
ASPEN	2007	RADIO (Radio)	V	V		V																																										
ASPEN	2007	SAS (Steering Angle Sensor)	V	V	V	V																																										
ASPEN	2007	SDAR (Satellite Radio)	V			V																																										
ASPEN	2007	CGW (Central Gateway)	V	V	V	V																																										
ASPEN	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND VOYAGER	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND VOYAGER	2016	ABS (Anti Lock Brake System)	V			V																																										
GRAND VOYAGER	2016	AHBM (Automatic High Beam)	V			V																																										
GRAND VOYAGER	2016	AMP (Audio)	V			V																																										
GRAND VOYAGER	2016	BCM (Body Control Module)	V			V																																										
GRAND VOYAGER	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
GRAND VOYAGER	2016	CGW (Central Gateway)	V			V																																										
GRAND VOYAGER	2016	HFM (Hands Free Module)	V			V																																										
GRAND VOYAGER	2016	HVAC (Heat Vent A/C)	V			V																																										
GRAND VOYAGER	2016	IPC (Instrument Panel Cluster)	V			V																																										
GRAND VOYAGER	2016	ITM (Intrusion)	V			V																																										
GRAND VOYAGER	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
GRAND VOYAGER	2016	MSMD (Memory Seet Module)	V			V																																										
GRAND VOYAGER	2016	ORC (Occupant Restraint Control)	V			V																																										
GRAND VOYAGER	2016	PTS (Park Assist Module)	V			V																																										
GRAND VOYAGER	2016	RADIO (Radio)	V			V																																										
GRAND VOYAGER	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
GRAND VOYAGER	2016	RFH (Radio Frequency Hub)	V			V																																										
GRAND VOYAGER	2016	SAS (Steering Angle Sensor)	V			V																																										
GRAND VOYAGER	2016	SUNR (Sunroof Module)	V			V																																										
GRAND VOYAGER	2016	TCM (Transmission Control Module)	V			V																																										
GRAND VOYAGER	2016	TPM (Tire Pressure Monitor)	V			V																																										
GRAND VOYAGER	2016	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND VOYAGER	2016	WCM(Wireless Control Modules)	V			V																																										
GRAND VOYAGER	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND VOYAGER	2015	ABS (Anti Lock Brake System)	V			V																																										
GRAND VOYAGER	2015	AHBM (Automatic High Beam)	V			V																																										
GRAND VOYAGER	2015	AMP (Audio)	V			V																																										
GRAND VOYAGER	2015	BCM (Body Control Module)	V			V																																										
GRAND VOYAGER	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
GRAND VOYAGER	2015	CGW (Central Gateway)	V			V																																										
GRAND VOYAGER	2015	HFM (Hands Free Module)	V			V																																										
GRAND VOYAGER	2015	HVAC (Heat Vent A/C)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND VOYAGER	2015	IPC (Instrument Panel Cluster)	V			V																																										
GRAND VOYAGER	2015	ITM (Intrusion)	V			V																																										
GRAND VOYAGER	2015	LBSS (Left Blind Spot Sensor)	V			V																																										
GRAND VOYAGER	2015	MSMD (Memory Seet Module)	V			V																																										
GRAND VOYAGER	2015	ORC (Occupant Restraint Control)	V			V																																										
GRAND VOYAGER	2015	PTS (Park Assist Module)	V			V																																										
GRAND VOYAGER	2015	RADIO (Radio)	V			V																																										
GRAND VOYAGER	2015	RBSS (Right Blind Spot Sensor)	V			V																																										
GRAND VOYAGER	2015	RFH (Radio Frequency Hub)	V			V																																										
GRAND VOYAGER	2015	SAS (Steering Angle Sensor)	V			V																																										
GRAND VOYAGER	2015	SUNR (Sunroof Module)	V			V																																										
GRAND VOYAGER	2015	TCM (Transmission Control Module)	V			V																																										
GRAND VOYAGER	2015	TPM (Tire Pressure Monitor)	V			V																																										
GRAND VOYAGER	2015	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND VOYAGER	2015	WCM(Wireless Control Modules)	V			V																																										
GRAND VOYAGER	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND VOYAGER	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
GRAND VOYAGER	2014	AHBM (Automatic High Beam)	V			V																																										
GRAND VOYAGER	2014	AMP (Audio)	V	V		V																																										
GRAND VOYAGER	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND VOYAGER	2014	HFM (Hands Free Module)	V	V	V	V																																										
GRAND VOYAGER	2014	HSM (Heated Seat Module)	V			V																																										
GRAND VOYAGER	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND VOYAGER	2014	ITM (Intrusion)	V			V																																										
GRAND VOYAGER	2014	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND VOYAGER	2014	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND VOYAGER	2014	PLM (Power Liftgate Module)	V			V																																										
GRAND VOYAGER	2014	PTS (Park Assist Module)	V			V																																										
GRAND VOYAGER	2014	RADIO (Radio)	V	V		V																																										
GRAND VOYAGER	2014	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND VOYAGER	2014	SUNR (Sunroof Module)	V			V																																										
GRAND VOYAGER	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND VOYAGER	2014	CGW (Central Gateway)	V	V	V	V																																										
GRAND VOYAGER	2014	TPM (Tire Pressure Monitor)	V			V																																										
GRAND VOYAGER	2014	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND VOYAGER	2014	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND VOYAGER	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND VOYAGER	2013	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
GRAND VOYAGER	2013	AHBM (Automatic High Beam)	V			V																																										
GRAND VOYAGER	2013	AMP (Audio)	V	V		V																																										
GRAND VOYAGER	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND VOYAGER	2013	HFM (Hands Free Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND VOYAGER	2013	HSM (Heated Seat Module)	V			V																																										
GRAND VOYAGER	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND VOYAGER	2013	ITM (Intrusion)	V			V																																										
GRAND VOYAGER	2013	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND VOYAGER	2013	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND VOYAGER	2013	PLM (Power Liftgate Module)	V			V																																										
GRAND VOYAGER	2013	PTS (Park Assist Module)	V			V																																										
GRAND VOYAGER	2013	RADIO (Radio)	V	V		V																																										
GRAND VOYAGER	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND VOYAGER	2013	SUNR (Sunroof Module)	V			V																																										
GRAND VOYAGER	2013	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
GRAND VOYAGER	2013	CGW (Central Gateway)	V	V	V	V																																										
GRAND VOYAGER	2013	TPM (Tire Pressure Monitor)	V			V																																										
GRAND VOYAGER	2013	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND VOYAGER	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND VOYAGER	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND VOYAGER	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND VOYAGER	2012	AHBM (Automatic High Beam)	V			V																																										
GRAND VOYAGER	2012	AMP (Audio)	V	V		V																																										
GRAND VOYAGER	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND VOYAGER	2012	HFM (Hands Free Module)	V	V	V	V																																										
GRAND VOYAGER	2012	HSM (Heated Seat Module)	V			V																																										
GRAND VOYAGER	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND VOYAGER	2012	ITM (Intrusion)	V			V																																										
GRAND VOYAGER	2012	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND VOYAGER	2012	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND VOYAGER	2012	PLM (Power Liftgate Module)	V			V																																										
GRAND VOYAGER	2012	PTS (Park Assist Module)	V			V																																										
GRAND VOYAGER	2012	RADIO (Radio)	V	V		V																																										
GRAND VOYAGER	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND VOYAGER	2012	SUNR (Sunroof Module)	V			V																																										
GRAND VOYAGER	2012	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
GRAND VOYAGER	2012	CGW (Central Gateway)	V	V	V	V																																										
GRAND VOYAGER	2012	TPM (Tire Pressure Monitor)	V			V																																										
GRAND VOYAGER	2012	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND VOYAGER	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND VOYAGER	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND VOYAGER	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND VOYAGER	2011	AHBM (Automatic High Beam)	V			V																																										
GRAND VOYAGER	2011	AMP (Audio)	V	V		V																																										
GRAND VOYAGER	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND VOYAGER	2011	HFM (Hands Free Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND VOYAGER	2011	HSM (Heated Seat Module)	V			V																																										
GRAND VOYAGER	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND VOYAGER	2011	ITM (Intrusion)	V			V																																										
GRAND VOYAGER	2011	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND VOYAGER	2011	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND VOYAGER	2011	PLM (Power Liftgate Module)	V			V																																										
GRAND VOYAGER	2011	PTS (Park Assist Module)	V			V																																										
GRAND VOYAGER	2011	RADIO (Radio)	V	V		V																																										
GRAND VOYAGER	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND VOYAGER	2011	SUNR (Sunroof Module)	V			V																																										
GRAND VOYAGER	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND VOYAGER	2011	CGW (Central Gateway)	V	V	V	V																																										
GRAND VOYAGER	2011	TPM (Tire Pressure Monitor)	V			V																																										
GRAND VOYAGER	2011	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND VOYAGER	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND VOYAGER	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND VOYAGER	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND VOYAGER	2010	AHBM (Automatic High Beam)	V			V																																										
GRAND VOYAGER	2010	AMP (Audio)	V	V		V																																										
GRAND VOYAGER	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND VOYAGER	2010	HFM (Hands Free Module)	V	V	V	V																																										
GRAND VOYAGER	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND VOYAGER	2010	ITM (Intrusion)	V			V																																										
GRAND VOYAGER	2010	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND VOYAGER	2010	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND VOYAGER	2010	PLM (Power Liftgate Module)	V			V																																										
GRAND VOYAGER	2010	PTS (Park Assist Module)	V			V																																										
GRAND VOYAGER	2010	RADIO (Radio)	V	V		V																																										
GRAND VOYAGER	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND VOYAGER	2010	SUNR (Sunroof Module)	V			V																																										
GRAND VOYAGER	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND VOYAGER	2010	CGW (Central Gateway)	V	V	V	V																																										
GRAND VOYAGER	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND VOYAGER	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND VOYAGER	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND VOYAGER	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND VOYAGER	2009	AHBM (Automatic High Beam)	V			V																																										
GRAND VOYAGER	2009	AMP (Audio)	V	V		V																																										
GRAND VOYAGER	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND VOYAGER	2009	HFM (Hands Free Module)	V	V	V	V																																										
GRAND VOYAGER	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND VOYAGER	2009	ITM (Intrusion)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND VOYAGER	2009	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND VOYAGER	2009	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND VOYAGER	2009	PLM (Power Liftgate Module)	V			V																																										
GRAND VOYAGER	2009	PTS (Park Assist Module)	V			V																																										
GRAND VOYAGER	2009	RADIO (Radio)	V	V		V																																										
GRAND VOYAGER	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND VOYAGER	2009	SUNR (Sunroof Module)	V			V																																										
GRAND VOYAGER	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND VOYAGER	2009	CGW (Central Gateway)	V	V	V	V																																										
GRAND VOYAGER	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND VOYAGER	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND VOYAGER	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND VOYAGER	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND VOYAGER	2008	AHBM (Automatic High Beam)	V			V																																										
GRAND VOYAGER	2008	AMP (Audio)	V	V		V																																										
GRAND VOYAGER	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND VOYAGER	2008	HFM (Hands Free Module)	V	V	V	V																																										
GRAND VOYAGER	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND VOYAGER	2008	ITM (Intrusion)	V			V																																										
GRAND VOYAGER	2008	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND VOYAGER	2008	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND VOYAGER	2008	PLM (Power Liftgate Module)	V			V																																										
GRAND VOYAGER	2008	PTS (Park Assist Module)	V			V																																										
GRAND VOYAGER	2008	RADIO (Radio)	V	V		V																																										
GRAND VOYAGER	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND VOYAGER	2008	SUNR (Sunroof Module)	V			V																																										
GRAND VOYAGER	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND VOYAGER	2008	CGW (Central Gateway)	V	V	V	V																																										
GRAND VOYAGER	2008	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND VOYAGER	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
PACIFICA	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PACIFICA	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
PACIFICA	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
PACIFICA	2008	ORC (Occupant Restraint Control)	V	V		V																																										
PACIFICA	2008	PLM (Power Liftgate Module)	V			V																																										
PACIFICA	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
PACIFICA	2008	CGW (Central Gateway)	V	V	V	V																																										
PACIFICA	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PACIFICA	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
PACIFICA	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
PACIFICA	2007	ORC (Occupant Restraint Control)	V	V		V																																										
PACIFICA	2007	PLM (Power Liftgate Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
PACIFICA	2007	SAS (Steering Angle Sensor)	V	V	V	V																																										
PACIFICA	2007	CGW (Central Gateway)	V	V	V	V																																										
PT CRUISER	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PT CRUISER	2010	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
PT CRUISER	2010	AMP (Audio)	V	V		V																																										
PT CRUISER	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PT CRUISER	2010	DDM (Drivers Door Module)	V	V	V	V																																										
PT CRUISER	2010	HFM (Hands Free Module)	V	V	V	V																																										
PT CRUISER	2010	ITM (Intrusion)	V			V																																										
PT CRUISER	2010	OCM (Occupant Classification Module)	V			V																																										
PT CRUISER	2010	ORC (Occupant Restraint Control)	V	V		V																																										
PT CRUISER	2010	PDM (Passenger Door Module)	V	V	V	V																																										
PT CRUISER	2010	RADIO (Radio)	V	V		V																																										
PT CRUISER	2010	SDAR (Satellite Radio)	V			V																																										
PT CRUISER	2010	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
PT CRUISER	2010	CGW (Central Gateway)	V	V	V	V																																										
PT CRUISER	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
PT CRUISER	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PT CRUISER	2009	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
PT CRUISER	2009	AMP (Audio)	V	V		V																																										
PT CRUISER	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PT CRUISER	2009	DDM (Drivers Door Module)	V	V	V	V																																										
PT CRUISER	2009	HFM (Hands Free Module)	V	V	V	V																																										
PT CRUISER	2009	ITM (Intrusion)	V			V																																										
PT CRUISER	2009	OCM (Occupant Classification Module)	V			V																																										
PT CRUISER	2009	ORC (Occupant Restraint Control)	V	V		V																																										
PT CRUISER	2009	PDM (Passenger Door Module)	V	V	V	V																																										
PT CRUISER	2009	RADIO (Radio)	V	V		V																																										
PT CRUISER	2009	SDAR (Satellite Radio)	V			V																																										
PT CRUISER	2009	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
PT CRUISER	2009	CGW (Central Gateway)	V	V	V	V																																										
PT CRUISER	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
PT CRUISER	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PT CRUISER	2008	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
PT CRUISER	2008	AMP (Audio)	V	V		V																																										
PT CRUISER	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PT CRUISER	2008	DDM (Drivers Door Module)	V	V	V	V																																										
PT CRUISER	2008	HFM (Hands Free Module)	V	V	V	V																																										
PT CRUISER	2008	ITM (Intrusion)	V			V																																										
PT CRUISER	2008	OCM (Occupant Classification Module)	V			V																																										
PT CRUISER	2008	ORC (Occupant Restraint Control)	V	V		V																																										
PT CRUISER	2008	PDM (Passenger Door Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
PT CRUISER	2008	RADIO (Radio)	V	V		V																																										
PT CRUISER	2008	SDAR (Satellite Radio)	V			V																																										
PT CRUISER	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
PT CRUISER	2008	CGW (Central Gateway)	V	V	V	V																																										
PT CRUISER	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
PT CRUISER	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PT CRUISER	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
PT CRUISER	2007	AMP (Audio)	V	V		V																																										
PT CRUISER	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PT CRUISER	2007	DDM (Drivers Door Module)	V	V	V	V																																										
PT CRUISER	2007	HFM (Hands Free Module)	V	V	V	V																																										
PT CRUISER	2007	ITM (Intrusion)	V			V																																										
PT CRUISER	2007	OCM (Occupant Classification Module)	V			V																																										
PT CRUISER	2007	ORC (Occupant Restraint Control)	V	V		V																																										
PT CRUISER	2007	PDM (Passenger Door Module)	V	V	V	V																																										
PT CRUISER	2007	RADIO (Radio)	V	V		V																																										
PT CRUISER	2007	SDAR (Satellite Radio)	V			V																																										
PT CRUISER	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
PT CRUISER	2007	CGW (Central Gateway)	V	V	V	V																																										
PT CRUISER	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
PT CRUISER	2006	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PT CRUISER	2006	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
PT CRUISER	2006	AMP (Audio)	V	V		V																																										
PT CRUISER	2006	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PT CRUISER	2006	DDM (Drivers Door Module)	V	V	V	V																																										
PT CRUISER	2006	HFM (Hands Free Module)	V	V	V	V																																										
PT CRUISER	2006	ITM (Intrusion)	V			V																																										
PT CRUISER	2006	OCM (Occupant Classification Module)	V			V																																										
PT CRUISER	2006	ORC (Occupant Restraint Control)	V	V		V																																										
PT CRUISER	2006	PDM (Passenger Door Module)	V	V	V	V																																										
PT CRUISER	2006	RADIO (Radio)	V	V		V																																										
PT CRUISER	2006	SDAR (Satellite Radio)	V			V																																										
PT CRUISER	2006	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
PT CRUISER	2006	CGW (Central Gateway)	V	V	V	V																																										
PT CRUISER	2006	WCM(Wireless Control Modules)	V	V	V	V																																										
SEBRING	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
SEBRING	2014	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
SEBRING	2014	AMP (Audio)	V	V		V																																										
SEBRING	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
SEBRING	2014	DDM (Drivers Door Module)	V	V	V	V																																										
SEBRING	2014	HFM (Hands Free Module)	V	V	V	V																																										
SEBRING	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
SEBRING	2014	ORC (Occupant Restraint Control)	V	V		V																																										
SEBRING	2014	PDM (Passenger Door Module)	V	V	V	V																																										
SEBRING	2014	RADIO (Radio)	V	V		V																																										
SEBRING	2014	SAS (Steering Angle Sensor)	V	V	V	V																																										
SEBRING	2014	CGW (Central Gateway)	V	V	V	V																																										
SEBRING	2014	WCM(Wireless Control Modules)	V	V	V	V																																										
SEBRING	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
SEBRING	2013	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
SEBRING	2013	AMP (Audio)	V	V		V																																										
SEBRING	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
SEBRING	2013	DDM (Drivers Door Module)	V	V	V	V																																										
SEBRING	2013	HFM (Hands Free Module)	V	V	V	V																																										
SEBRING	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
SEBRING	2013	ORC (Occupant Restraint Control)	V	V		V																																										
SEBRING	2013	PDM (Passenger Door Module)	V	V	V	V																																										
SEBRING	2013	RADIO (Radio)	V	V		V																																										
SEBRING	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
SEBRING	2013	CGW (Central Gateway)	V	V	V	V																																										
SEBRING	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
SEBRING	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
SEBRING	2012	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
SEBRING	2012	AMP (Audio)	V	V		V																																										
SEBRING	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
SEBRING	2012	DDM (Drivers Door Module)	V	V	V	V																																										
SEBRING	2012	HFM (Hands Free Module)	V	V	V	V																																										
SEBRING	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
SEBRING	2012	ORC (Occupant Restraint Control)	V	V		V																																										
SEBRING	2012	PDM (Passenger Door Module)	V	V	V	V																																										
SEBRING	2012	RADIO (Radio)	V	V		V																																										
SEBRING	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
SEBRING	2012	CGW (Central Gateway)	V	V	V	V																																										
SEBRING	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
SEBRING	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
SEBRING	2011	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
SEBRING	2011	AMP (Audio)	V	V		V																																										
SEBRING	2011	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
SEBRING	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
SEBRING	2011	DDM (Drivers Door Module)	V	V	V	V																																										
SEBRING	2011	ESM (Electronic Shifter Module)	V			V																																										
SEBRING	2011	HFM (Hands Free Module)	V	V	V	V																																										
SEBRING	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
SEBRING	2011	ITM (Intrusion)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
SEBRING	2011	ORC (Occupant Restraint Control)	V	V		V																																										
SEBRING	2011	PDM (Passenger Door Module)	V	V	V	V																																										
SEBRING	2011	RADIO (Radio)	V	V		V																																										
SEBRING	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
SEBRING	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
SEBRING	2011	CGW (Central Gateway)	V	V	V	V																																										
SEBRING	2011	VES3 (Vidio Entertainment System 3)	V			V																																										
SEBRING	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
SEBRING	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
SEBRING	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
SEBRING	2010	AMP (Audio)	V	V		V																																										
SEBRING	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
SEBRING	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
SEBRING	2010	DDM (Drivers Door Module)	V	V	V	V																																										
SEBRING	2010	HFM (Hands Free Module)	V	V	V	V																																										
SEBRING	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
SEBRING	2010	ITM (Intrusion)	V			V																																										
SEBRING	2010	ORC (Occupant Restraint Control)	V	V		V																																										
SEBRING	2010	PDM (Passenger Door Module)	V	V	V	V																																										
SEBRING	2010	RADIO (Radio)	V	V		V																																										
SEBRING	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
SEBRING	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
SEBRING	2010	CGW (Central Gateway)	V	V	V	V																																										
SEBRING	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
SEBRING	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
SEBRING	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
SEBRING	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
SEBRING	2009	AMP (Audio)	V	V		V																																										
SEBRING	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
SEBRING	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
SEBRING	2009	DDM (Drivers Door Module)	V	V	V	V																																										
SEBRING	2009	HFM (Hands Free Module)	V	V	V	V																																										
SEBRING	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
SEBRING	2009	ITM (Intrusion)	V			V																																										
SEBRING	2009	ORC (Occupant Restraint Control)	V	V		V																																										
SEBRING	2009	PDM (Passenger Door Module)	V	V	V	V																																										
SEBRING	2009	RADIO (Radio)	V	V		V																																										
SEBRING	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
SEBRING	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
SEBRING	2009	CGW (Central Gateway)	V	V	V	V																																										
SEBRING	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
SEBRING	2009	WCM(Wireless Control Modules)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
SEBRING	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
SEBRING	2008	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
SEBRING	2008	AMP (Audio)	V	V		V																																									
SEBRING	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																									
SEBRING	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																									
SEBRING	2008	DDM (Drivers Door Module)	V	V	V	V																																									
SEBRING	2008	HFM (Hands Free Module)	V	V	V	V																																									
SEBRING	2008	HVAC (Heat Vent A/C)	V	V	V	V																																									
SEBRING	2008	ITM (Intrusion)	V			V																																									
SEBRING	2008	ORC (Occupant Restraint Control)	V	V		V																																									
SEBRING	2008	PDM (Passenger Door Module)	V	V	V	V																																									
SEBRING	2008	RADIO (Radio)	V	V		V																																									
SEBRING	2008	SAS (Steering Angle Sensor)	V	V	V	V																																									
SEBRING	2008	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
SEBRING	2008	CGW (Central Gateway)	V	V	V	V																																									
SEBRING	2008	VES3 (Vidio Entertainment System 3)	V			V																																									
SEBRING	2008	WCM(Wireless Control Modules)	V	V	V	V																																									
SEBRING	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
SEBRING	2007	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
SEBRING	2007	AMP (Audio)	V	V		V																																									
SEBRING	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																									
SEBRING	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																									
SEBRING	2007	DDM (Drivers Door Module)	V	V	V	V																																									
SEBRING	2007	HFM (Hands Free Module)	V	V	V	V																																									
SEBRING	2007	HVAC (Heat Vent A/C)	V	V	V	V																																									
SEBRING	2007	ITM (Intrusion)	V			V																																									
SEBRING	2007	ORC (Occupant Restraint Control)	V	V		V																																									
SEBRING	2007	PDM (Passenger Door Module)	V	V	V	V																																									
SEBRING	2007	RADIO (Radio)	V	V		V																																									
SEBRING	2007	SAS (Steering Angle Sensor)	V	V	V	V																																									
SEBRING	2007	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
SEBRING	2007	CGW (Central Gateway)	V	V	V	V																																									
SEBRING	2007	VES3 (Vidio Entertainment System 3)	V			V																																									
SEBRING	2007	WCM(Wireless Control Modules)	V	V	V	V																																									
TOWN/COUNTRY	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
TOWN/COUNTRY	2016	ABS (Anti Lock Brake System)	V			V																																									
TOWN/COUNTRY	2016	AHBM (Automatic High Beam)	V			V																																									
TOWN/COUNTRY	2016	AMP (Audio)	V			V																																									
TOWN/COUNTRY	2016	BCM (Body Control Module)	V			V																																									
TOWN/COUNTRY	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																									
TOWN/COUNTRY	2016	CGW (Central Gateway)	V			V																																									
TOWN/COUNTRY	2016	HFM (Hands Free Module)	V			V																																									

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
TOWN/COUNTRY	2016	HVAC (Heat Vent A/C)	V			V																																										
TOWN/COUNTRY	2016	IPC (Instrument Panel Cluster)	V			V																																										
TOWN/COUNTRY	2016	ITM (Intrusion)	V			V																																										
TOWN/COUNTRY	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
TOWN/COUNTRY	2016	MSMD (Memory Seet Module)	V			V																																										
TOWN/COUNTRY	2016	ORC (Occupant Restraint Control)	V			V																																										
TOWN/COUNTRY	2016	PTS (Park Assist Module)	V			V																																										
TOWN/COUNTRY	2016	RADIO (Radio)	V			V																																										
TOWN/COUNTRY	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
TOWN/COUNTRY	2016	RFH (Radio Frequency Hub)	V			V																																										
TOWN/COUNTRY	2016	SAS (Steering Angle Sensor)	V			V																																										
TOWN/COUNTRY	2016	SUNR (Sunroof Module)	V			V																																										
TOWN/COUNTRY	2016	TCM (Transmission Control Module)	V			V																																										
TOWN/COUNTRY	2016	TPM (Tire Pressure Monitor)	V			V																																										
TOWN/COUNTRY	2016	VES3 (Vidio Entertainment System 3)	V			V																																										
TOWN/COUNTRY	2016	WCM(Wireless Control Modules)	V			V																																										
TOWN/COUNTRY	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
TOWN/COUNTRY	2015	ABS (Anti Lock Brake System)	V			V																																										
TOWN/COUNTRY	2015	AHBM (Automatic High Beam)	V			V																																										
TOWN/COUNTRY	2015	AMP (Audio)	V			V																																										
TOWN/COUNTRY	2015	BCM (Body Control Module)	V			V																																										
TOWN/COUNTRY	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
TOWN/COUNTRY	2015	CGW (Central Gateway)	V			V																																										
TOWN/COUNTRY	2015	HFM (Hands Free Module)	V			V																																										
TOWN/COUNTRY	2015	HVAC (Heat Vent A/C)	V			V																																										
TOWN/COUNTRY	2015	IPC (Instrument Panel Cluster)	V			V																																										
TOWN/COUNTRY	2015	ITM (Intrusion)	V			V																																										
TOWN/COUNTRY	2015	LBSS (Left Blind Spot Sensor)	V			V																																										
TOWN/COUNTRY	2015	MSMD (Memory Seet Module)	V			V																																										
TOWN/COUNTRY	2015	ORC (Occupant Restraint Control)	V			V																																										
TOWN/COUNTRY	2015	PTS (Park Assist Module)	V			V																																										
TOWN/COUNTRY	2015	RADIO (Radio)	V			V																																										
TOWN/COUNTRY	2015	RBSS (Right Blind Spot Sensor)	V			V																																										
TOWN/COUNTRY	2015	RFH (Radio Frequency Hub)	V			V																																										
TOWN/COUNTRY	2015	SAS (Steering Angle Sensor)	V			V																																										
TOWN/COUNTRY	2015	SUNR (Sunroof Module)	V			V																																										
TOWN/COUNTRY	2015	TCM (Transmission Control Module)	V			V																																										
TOWN/COUNTRY	2015	TPM (Tire Pressure Monitor)	V			V																																										
TOWN/COUNTRY	2015	VES3 (Vidio Entertainment System 3)	V			V																																										
TOWN/COUNTRY	2015	WCM(Wireless Control Modules)	V			V																																										
TOWN/COUNTRY	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
TOWN/COUNTRY	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
TOWN/COUNTRY	2014	AHBM (Automatic High Beam)	V			V																																										
TOWN/COUNTRY	2014	AMP (Audio)	V	V		V																																										
TOWN/COUNTRY	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
TOWN/COUNTRY	2014	HFM (Hands Free Module)	V	V	V	V																																										
TOWN/COUNTRY	2014	HSM (Heated Seat Module)	V			V																																										
TOWN/COUNTRY	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
TOWN/COUNTRY	2014	ITM (Intrusion)	V			V																																										
TOWN/COUNTRY	2014	MSMD (Memory Seet Module)	V	V	V	V																																										
TOWN/COUNTRY	2014	ORC (Occupant Restraint Control)	V	V		V																																										
TOWN/COUNTRY	2014	PLM (Power Liftgate Module)	V			V																																										
TOWN/COUNTRY	2014	PTS (Park Assist Module)	V			V																																										
TOWN/COUNTRY	2014	RADIO (Radio)	V	V		V																																										
TOWN/COUNTRY	2014	SAS (Steering Angle Sensor)	V	V	V	V																																										
TOWN/COUNTRY	2014	SUNR (Sunroof Module)	V			V																																										
TOWN/COUNTRY	2014	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
TOWN/COUNTRY	2014	CGW (Central Gateway)	V	V	V	V																																										
TOWN/COUNTRY	2014	TPM (Tire Pressure Monitor)	V			V																																										
TOWN/COUNTRY	2014	VES3 (Vidio Entertainment System 3)	V			V																																										
TOWN/COUNTRY	2014	WCM(Wireless Control Modules)	V	V	V	V																																										
TOWN/COUNTRY	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
TOWN/COUNTRY	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
TOWN/COUNTRY	2013	AHBM (Automatic High Beam)	V			V																																										
TOWN/COUNTRY	2013	AMP (Audio)	V	V		V																																										
TOWN/COUNTRY	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
TOWN/COUNTRY	2013	HFM (Hands Free Module)	V	V	V	V																																										
TOWN/COUNTRY	2013	HSM (Heated Seat Module)	V			V																																										
TOWN/COUNTRY	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
TOWN/COUNTRY	2013	ITM (Intrusion)	V			V																																										
TOWN/COUNTRY	2013	MSMD (Memory Seet Module)	V	V	V	V																																										
TOWN/COUNTRY	2013	ORC (Occupant Restraint Control)	V	V		V																																										
TOWN/COUNTRY	2013	PLM (Power Liftgate Module)	V			V																																										
TOWN/COUNTRY	2013	PTS (Park Assist Module)	V			V																																										
TOWN/COUNTRY	2013	RADIO (Radio)	V	V		V																																										
TOWN/COUNTRY	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
TOWN/COUNTRY	2013	SUNR (Sunroof Module)	V			V																																										
TOWN/COUNTRY	2013	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
TOWN/COUNTRY	2013	CGW (Central Gateway)	V	V	V	V																																										
TOWN/COUNTRY	2013	TPM (Tire Pressure Monitor)	V			V																																										
TOWN/COUNTRY	2013	VES3 (Vidio Entertainment System 3)	V			V																																										
TOWN/COUNTRY	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
TOWN/COUNTRY	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
TOWN/COUNTRY	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
TOWN/COUNTRY	2012	AHBM (Automatic High Beam)	V			V																																										
TOWN/COUNTRY	2012	AMP (Audio)	V	V		V																																										
TOWN/COUNTRY	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
TOWN/COUNTRY	2012	HFM (Hands Free Module)	V	V	V	V																																										
TOWN/COUNTRY	2012	HSM (Heated Seat Module)	V			V																																										
TOWN/COUNTRY	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
TOWN/COUNTRY	2012	ITM (Intrusion)	V			V																																										
TOWN/COUNTRY	2012	MSMD (Memory Seet Module)	V	V	V	V																																										
TOWN/COUNTRY	2012	ORC (Occupant Restraint Control)	V	V		V																																										
TOWN/COUNTRY	2012	PLM (Power Liftgate Module)	V			V																																										
TOWN/COUNTRY	2012	PTS (Park Assist Module)	V			V																																										
TOWN/COUNTRY	2012	RADIO (Radio)	V	V		V																																										
TOWN/COUNTRY	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
TOWN/COUNTRY	2012	SUNR (Sunroof Module)	V			V																																										
TOWN/COUNTRY	2012	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
TOWN/COUNTRY	2012	CGW (Central Gateway)	V	V	V	V																																										
TOWN/COUNTRY	2012	TPM (Tire Pressure Monitor)	V			V																																										
TOWN/COUNTRY	2012	VES3 (Vidio Entertainment System 3)	V			V																																										
TOWN/COUNTRY	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
TOWN/COUNTRY	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
TOWN/COUNTRY	2011	AHBM (Automatic High Beam)	V			V																																										
TOWN/COUNTRY	2011	AMP (Audio)	V	V		V																																										
TOWN/COUNTRY	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
TOWN/COUNTRY	2011	HFM (Hands Free Module)	V	V	V	V																																										
TOWN/COUNTRY	2011	HSM (Heated Seat Module)	V			V																																										
TOWN/COUNTRY	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
TOWN/COUNTRY	2011	ITM (Intrusion)	V			V																																										
TOWN/COUNTRY	2011	MSMD (Memory Seet Module)	V	V	V	V																																										
TOWN/COUNTRY	2011	ORC (Occupant Restraint Control)	V	V		V																																										
TOWN/COUNTRY	2011	PLM (Power Liftgate Module)	V			V																																										
TOWN/COUNTRY	2011	PTS (Park Assist Module)	V			V																																										
TOWN/COUNTRY	2011	RADIO (Radio)	V	V		V																																										
TOWN/COUNTRY	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
TOWN/COUNTRY	2011	SUNR (Sunroof Module)	V			V																																										
TOWN/COUNTRY	2011	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
TOWN/COUNTRY	2011	CGW (Central Gateway)	V	V	V	V																																										
TOWN/COUNTRY	2011	TPM (Tire Pressure Monitor)	V			V																																										
TOWN/COUNTRY	2011	VES3 (Vidio Entertainment System 3)	V			V																																										
TOWN/COUNTRY	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
TOWN/COUNTRY	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
TOWN/COUNTRY	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
TOWN/COUNTRY	2010	AHBM (Automatic High Beam)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
TOWN/COUNTRY	2010	AMP (Audio)	V	V		V																																										
TOWN/COUNTRY	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
TOWN/COUNTRY	2010	HFM (Hands Free Module)	V	V	V	V																																										
TOWN/COUNTRY	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
TOWN/COUNTRY	2010	ITM (Intrusion)	V			V																																										
TOWN/COUNTRY	2010	MSMD (Memory Seet Module)	V	V	V	V																																										
TOWN/COUNTRY	2010	ORC (Occupant Restraint Control)	V	V		V																																										
TOWN/COUNTRY	2010	PLM (Power Liftgate Module)	V			V																																										
TOWN/COUNTRY	2010	PTS (Park Assist Module)	V			V																																										
TOWN/COUNTRY	2010	RADIO (Radio)	V	V		V																																										
TOWN/COUNTRY	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
TOWN/COUNTRY	2010	SUNR (Sunroof Module)	V			V																																										
TOWN/COUNTRY	2010	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
TOWN/COUNTRY	2010	CGW (Central Gateway)	V	V	V	V																																										
TOWN/COUNTRY	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
TOWN/COUNTRY	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
TOWN/COUNTRY	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
TOWN/COUNTRY	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
TOWN/COUNTRY	2009	AHBM (Automatic High Beam)	V			V																																										
TOWN/COUNTRY	2009	AMP (Audio)	V	V		V																																										
TOWN/COUNTRY	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
TOWN/COUNTRY	2009	HFM (Hands Free Module)	V	V	V	V																																										
TOWN/COUNTRY	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
TOWN/COUNTRY	2009	ITM (Intrusion)	V			V																																										
TOWN/COUNTRY	2009	MSMD (Memory Seet Module)	V	V	V	V																																										
TOWN/COUNTRY	2009	ORC (Occupant Restraint Control)	V	V		V																																										
TOWN/COUNTRY	2009	PLM (Power Liftgate Module)	V			V																																										
TOWN/COUNTRY	2009	PTS (Park Assist Module)	V			V																																										
TOWN/COUNTRY	2009	RADIO (Radio)	V	V		V																																										
TOWN/COUNTRY	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
TOWN/COUNTRY	2009	SUNR (Sunroof Module)	V			V																																										
TOWN/COUNTRY	2009	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
TOWN/COUNTRY	2009	CGW (Central Gateway)	V	V	V	V																																										
TOWN/COUNTRY	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
TOWN/COUNTRY	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
TOWN/COUNTRY	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
TOWN/COUNTRY	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
TOWN/COUNTRY	2008	AHBM (Automatic High Beam)	V			V																																										
TOWN/COUNTRY	2008	AMP (Audio)	V	V		V																																										
TOWN/COUNTRY	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
TOWN/COUNTRY	2008	HFM (Hands Free Module)	V	V	V	V																																										
TOWN/COUNTRY	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
TOWN/COUNTRY	2008	ITM (Intrusion)	V			V																																										
TOWN/COUNTRY	2008	MSMD (Memory Seet Module)	V	V	V	V																																										
TOWN/COUNTRY	2008	ORC (Occupant Restraint Control)	V	V		V																																										
TOWN/COUNTRY	2008	PLM (Power Liftgate Module)	V			V																																										
TOWN/COUNTRY	2008	PTS (Park Assist Module)	V			V																																										
TOWN/COUNTRY	2008	RADIO (Radio)	V	V		V																																										
TOWN/COUNTRY	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
TOWN/COUNTRY	2008	SUNR (Sunroof Module)	V			V																																										
TOWN/COUNTRY	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
TOWN/COUNTRY	2008	CGW (Central Gateway)	V	V	V	V																																										
TOWN/COUNTRY	2008	VES3 (Vidio Entertainment System 3)	V			V																																										
TOWN/COUNTRY	2008	WCM(Wireless Control Modules)	V	V	V	V																																										

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
General(CAN Bus)	ALL	PCM (Powertrain Control Module)																																														
General(CAN Bus)	ALL	ABS (Anti Lock Brake System)	V																																													
General(CAN Bus)	ALL	ACC (Adaptive Cruise Control)																																														
General(CAN Bus)	ALL	ADCM (Adaptive Damper Control Module)																																														
General(CAN Bus)	ALL	AFLS (Adaptive Front Light System)																																														
General(CAN Bus)	ALL	AHBM (Automatic High Beam)																																														
General(CAN Bus)	ALL	AMP (Audio)																						V	V																							
General(CAN Bus)	ALL	BCM (Body Control Module)																																														
General(CAN Bus)	ALL	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
General(CAN Bus)	ALL	FFCM (Front Facing Camera Module)																																													V	
General(CAN Bus)	ALL	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
General(CAN Bus)	ALL	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
General(CAN Bus)	ALL	DDM (Drivers Door Module)																					V																										
General(CAN Bus)	ALL	DTCM (Drive Train Control Module)																																														
General(CAN Bus)	ALL	EDM (Electronic Damper Module)																																														
General(CAN Bus)	ALL	EOM (Electric Overhead Module)																																											V			
General(CAN Bus)	ALL	EPB (Electrical Parking Brake)																																														V
General(CAN Bus)	ALL	EPS (Electric Power Steering)																																														
General(CAN Bus)	ALL	ESM (Electronic Shifter Module)																																														
General(CAN Bus)	ALL	HFM (Hands Free Module)																																								V						
General(CAN Bus)	ALL	HSM (Heated Seat Module)																																														
General(CAN Bus)	ALL	HVAC (Heat Vent A/C)																								V	V	V	V																			
General(CAN Bus)	ALL	ICS (Integrated Center Stack)																																														
General(CAN Bus)	ALL	IPC (Instrument Panel Cluster)																																														
General(CAN Bus)	ALL	ITM (Intrusion)																																														
General(CAN Bus)	ALL	LBSS (Left Blind Spot Sensor)																																														
General(CAN Bus)	ALL	LRSM (Light Rain Sensor Module)																																														
General(CAN Bus)	ALL	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
General(CAN Bus)	ALL	OCM (Occupant Classification Module)																																														
General(CAN Bus)	ALL	ORC (Occupant Restraint Control)		V																																												
General(CAN Bus)	ALL	PDM (Passenger Door Module)																																														
General(CAN Bus)	ALL	PLM (Power Liftgate Module)																																														
General(CAN Bus)	ALL	PTS (Park Assist Module)																																														
General(CAN Bus)	ALL	RADIO (Radio)																																				V	V	V	V							
General(CAN Bus)	ALL	RBSS (Right Blind Spot Sensor)																																														
General(CAN Bus)	ALL	RFH (Radio Frequency Hub)																																														
General(CAN Bus)	ALL	SAS (Steering Angle Sensor)																																														
General(CAN Bus)	ALL	SCM (Steering Column Module)																																														
General(CAN Bus)	ALL	SDAR (Satellite Radio)																																														
General(CAN Bus)	ALL	SUNR (Sunroof Module)																																														
General(CAN Bus)	ALL	TCM (Transmission Control Module)																																														
General(CAN Bus)	ALL	TGW (Telematics Gateway)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
General(CAN Bus)	ALL	TPM (Tire Pressure Monitor)																																														
General(CAN Bus)	ALL	VES3 (Vidio Entertainment System 3)																																														
General(CAN Bus)	ALL	WCM(Wireless Control Modules)														V																											V	V				
200	2016	PCM (Powertrain Control Module)																																														
200	2016	ABS (Anti Lock Brake System)																																														
200	2016	ACC (Adaptive Cruise Control)																																														
200	2016	AMP (Audio)																																														
200	2016	BCM (Body Control Module)																																														
200	2016	FFCM (Front Facing Camera Module)																																													V	
200	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
200	2016	CGW (Central Gateway)																																														
200	2016	DDM (Drivers Door Module)																																														
200	2016	DTCM (Drive Train Control Module)																																														
200	2016	EPB (Electrical Parking Brake)																																														V
200	2016	EPS (Electric Power Steering)																																														
200	2016	ESM (Electronic Shifter Module)																																														
200	2016	HVAC (Heat Vent A/C)																																														
200	2016	ICS (Integrated Center Stack)																																														
200	2016	IPC (Instrument Panel Cluster)																																														
200	2016	LBSS (Left Blind Spot Sensor)																																														
200	2016	MSMD (Memory Seet Module)																																														
200	2016	OCM (Occupant Classification Module)																																														
200	2016	ORC (Occupant Restraint Control)																																														
200	2016	PDM (Passenger Door Module)																																														
200	2016	RADIO (Radio)																																														
200	2016	RBSS (Right Blind Spot Sensor)																																														
200	2016	RFH (Radio Frequency Hub)																																														
200	2016	SCM (Steering Column Module)																																														
200	2016	TCM (Transmission Control Module)																																														
200	2016	WCM(Wireless Control Modules)																																														
200	2015	PCM (Powertrain Control Module)																																														
200	2015	ABS (Anti Lock Brake System)																																														
200	2015	ACC (Adaptive Cruise Control)																																														
200	2015	AMP (Audio)																																														
200	2015	BCM (Body Control Module)																																														
200	2015	FFCM (Front Facing Camera Module)																																													V	
200	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
200	2015	CGW (Central Gateway)																																														
200	2015	DDM (Drivers Door Module)																																														
200	2015	DTCM (Drive Train Control Module)																																														
200	2015	EPB (Electrical Parking Brake)																																														V
200	2015	EPS (Electric Power Steering)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
200	2015	ESM (Electronic Shifter Module)																																														
200	2015	HVAC (Heat Vent A/C)																																														
200	2015	ICS (Integrated Center Stack)																																														
200	2015	IPC (Instrument Panel Cluster)																																														
200	2015	LBSS (Left Blind Spot Sensor)																																														
200	2015	MSMD (Memory Seet Module)																																														
200	2015	OCM (Occupant Classification Module)																																														
200	2015	ORC (Occupant Restraint Control)																																														
200	2015	PDM (Passenger Door Module)																																														
200	2015	RADIO (Radio)																																														
200	2015	RBSS (Right Blind Spot Sensor)																																														
200	2015	RFH (Radio Frequency Hub)																																														
200	2015	SCM (Steering Column Module)																																														
200	2015	TCM (Transmission Control Module)																																														
200	2015	WCM(Wireless Control Modules)																																														
200	2014	PCM (Powertrain Control Module)																																														
200	2014	ABS (Anti Lock Brake System)	V																																													
200	2014	AMP (Audio)																						V	V																							
200	2014	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
200	2014	DDM (Drivers Door Module)																					V																									
200	2014	HFM (Hands Free Module)																																								V						
200	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
200	2014	ORC (Occupant Restraint Control)		V																																												
200	2014	PDM (Passenger Door Module)																																														
200	2014	RADIO (Radio)																																				V	V	V	V							
200	2014	SAS (Steering Angle Sensor)																																														
200	2014	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
200	2014	WCM(Wireless Control Modules)														V																											V	V				
200	2013	PCM (Powertrain Control Module)																																														
200	2013	ABS (Anti Lock Brake System)	V																																													
200	2013	AMP (Audio)																						V	V																							
200	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
200	2013	DDM (Drivers Door Module)																					V																									
200	2013	HFM (Hands Free Module)																																								V						
200	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
200	2013	ORC (Occupant Restraint Control)		V																																												
200	2013	PDM (Passenger Door Module)																																														
200	2013	RADIO (Radio)																																				V	V	V	V							
200	2013	SAS (Steering Angle Sensor)																																														
200	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
200	2013	WCM(Wireless Control Modules)														V																											V	V				
200	2012	PCM (Powertrain Control Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
200	2012	ABS (Anti Lock Brake System)	V																																													
200	2012	AMP (Audio)																						V	V																							
200	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
200	2012	DDM (Drivers Door Module)																					V																									
200	2012	HFM (Hands Free Module)																																								V						
200	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
200	2012	ORC (Occupant Restraint Control)		V																																												
200	2012	PDM (Passenger Door Module)																																														
200	2012	RADIO (Radio)																																				V	V	V	V							
200	2012	SAS (Steering Angle Sensor)																																														
200	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
200	2012	WCM(Wireless Control Modules)														V																											V	V				
200	2011	PCM (Powertrain Control Module)																																														
200	2011	ABS (Anti Lock Brake System)	V																																													
200	2011	AMP (Audio)																						V	V																							
200	2011	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
200	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
200	2011	DDM (Drivers Door Module)																					V																									
200	2011	ESM (Electronic Shifter Module)																																														
200	2011	HFM (Hands Free Module)																																								V						
200	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
200	2011	ITM (Intrusion)																																														
200	2011	ORC (Occupant Restraint Control)		V																																												
200	2011	PDM (Passenger Door Module)																																														
200	2011	RADIO (Radio)																																				V	V	V	V							
200	2011	SAS (Steering Angle Sensor)																																														
200	2011	TCM (Transmission Control Module)																																														
200	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
200	2011	VES3 (Vidio Entertainment System 3)																																														
200	2011	WCM(Wireless Control Modules)														V																											V	V				
200	2010	PCM (Powertrain Control Module)																																														
200	2010	ABS (Anti Lock Brake System)	V																																													
200	2010	AMP (Audio)																						V	V																							
200	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
200	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
200	2010	DDM (Drivers Door Module)																					V																									
200	2010	HFM (Hands Free Module)																																								V						
200	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
200	2010	ITM (Intrusion)																																														
200	2010	ORC (Occupant Restraint Control)		V																																												
200	2010	PDM (Passenger Door Module)																																														
200	2010	RADIO (Radio)																																				V	V	V	V							

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
200	2010	SAS (Steering Angle Sensor)																																														
200	2010	TCM (Transmission Control Module)																																														
200	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
200	2010	VES3 (Vidio Entertainment System 3)																																														
200	2010	WCM(Wireless Control Modules)														V																											V	V				
200	2009	PCM (Powertrain Control Module)																																														
200	2009	ABS (Anti Lock Brake System)	V																																													
200	2009	AMP (Audio)																						V	V																							
200	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
200	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
200	2009	DDM (Drivers Door Module)																					V																									
200	2009	HFM (Hands Free Module)																																								V						
200	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
200	2009	ITM (Intrusion)																																														
200	2009	ORC (Occupant Restraint Control)		V																																												
200	2009	PDM (Passenger Door Module)																																														
200	2009	RADIO (Radio)																																				V	V	V	V							
200	2009	SAS (Steering Angle Sensor)																																														
200	2009	TCM (Transmission Control Module)																																														
200	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
200	2009	VES3 (Vidio Entertainment System 3)																																														
200	2009	WCM(Wireless Control Modules)														V																											V	V				
200	2008	PCM (Powertrain Control Module)																																														
200	2008	ABS (Anti Lock Brake System)	V																																													
200	2008	AMP (Audio)																						V	V																							
200	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
200	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
200	2008	DDM (Drivers Door Module)																					V																									
200	2008	HFM (Hands Free Module)																																								V						
200	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
200	2008	ITM (Intrusion)																																														
200	2008	ORC (Occupant Restraint Control)		V																																												
200	2008	PDM (Passenger Door Module)																																														
200	2008	RADIO (Radio)																																				V	V	V	V							
200	2008	SAS (Steering Angle Sensor)																																														
200	2008	TCM (Transmission Control Module)																																														
200	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
200	2008	VES3 (Vidio Entertainment System 3)																																														
200	2008	WCM(Wireless Control Modules)														V																											V	V				
200	2007	PCM (Powertrain Control Module)																																														
200	2007	ABS (Anti Lock Brake System)	V																																													
200	2007	AMP (Audio)																						V	V																							

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
200	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
200	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
200	2007	DDM (Drivers Door Module)																					V																									
200	2007	HFM (Hands Free Module)																																								V						
200	2007	HVAC (Heat Vent A/C)																								V	V	V	V																			
200	2007	ITM (Intrusion)																																														
200	2007	ORC (Occupant Restraint Control)		V																																												
200	2007	PDM (Passenger Door Module)																																														
200	2007	RADIO (Radio)																																				V	V	V	V							
200	2007	SAS (Steering Angle Sensor)																																														
200	2007	TCM (Transmission Control Module)																																														
200	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
200	2007	VES3 (Vidio Entertainment System 3)																																														
200	2007	WCM(Wireless Control Modules)														V																											V	V				
300	2016	PCM (Powertrain Control Module)																																														
300	2016	ABS (Anti Lock Brake System)																																														
300	2016	ACC (Adaptive Cruise Control)																																														
300	2016	ADCM (Adaptive Damper Control Module)																																														
300	2016	AFLS (Adaptive Front Light System)																																														
300	2016	AMP (Audio)																																														
300	2016	BCM (Body Control Module)																																														
300	2016	FFCM (Front Facing Camera Module)																																													V	
300	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
300	2016	CGW (Central Gateway)																																														
300	2016	DDM (Drivers Door Module)																																														
300	2016	DTCM (Drive Train Control Module)																																														
300	2016	EPS (Electric Power Steering)																																														
300	2016	ESM (Electronic Shifter Module)																																														
300	2016	HSM (Heated Seat Module)																																														
300	2016	HVAC (Heat Vent A/C)																																														
300	2016	ICS (Integrated Center Stack)																																														
300	2016	IPC (Instrument Panel Cluster)																																														
300	2016	ITM (Intrusion)																																														
300	2016	LBSS (Left Blind Spot Sensor)																																														
300	2016	ORC (Occupant Restraint Control)																																														
300	2016	PDM (Passenger Door Module)																																														
300	2016	PTS (Park Assist Module)																																														
300	2016	RADIO (Radio)																																														
300	2016	RBSS (Right Blind Spot Sensor)																																														
300	2016	RFH (Radio Frequency Hub)																																														
300	2016	SCM (Steering Column Module)																																														
300	2016	TCM (Transmission Control Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
300	2016	WCM(Wireless Control Modules)																																													
300	2015	PCM (Powertrain Control Module)																																													
300	2015	ABS (Anti Lock Brake System)																																													
300	2015	ACC (Adaptive Cruise Control)																																													
300	2015	ADCM (Adaptive Damper Control Module)																																													
300	2015	AFLS (Adaptive Front Light System)																																													
300	2015	AMP (Audio)																																													
300	2015	BCM (Body Control Module)																																													
300	2015	FFCM (Front Facing Camera Module)																																												V	
300	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																													
300	2015	CGW (Central Gateway)																																													
300	2015	DDM (Drivers Door Module)																																													
300	2015	DTCM (Drive Train Control Module)																																													
300	2015	EPS (Electric Power Steering)																																													
300	2015	ESM (Electronic Shifter Module)																																													
300	2015	HSM (Heated Seat Module)																																													
300	2015	HVAC (Heat Vent A/C)																																													
300	2015	ICS (Integrated Center Stack)																																													
300	2015	IPC (Instrument Panel Cluster)																																													
300	2015	ITM (Intrusion)																																													
300	2015	LBSS (Left Blind Spot Sensor)																																													
300	2015	ORC (Occupant Restraint Control)																																													
300	2015	PDM (Passenger Door Module)																																													
300	2015	PTS (Park Assist Module)																																													
300	2015	RADIO (Radio)																																													
300	2015	RBSS (Right Blind Spot Sensor)																																													
300	2015	RFH (Radio Frequency Hub)																																													
300	2015	SCM (Steering Column Module)																																													
300	2015	TCM (Transmission Control Module)																																													
300	2015	WCM(Wireless Control Modules)																																													
300	2014	PCM (Powertrain Control Module)																																													
300	2014	ABS (Anti Lock Brake System)	V																																												
300	2014	ACC (Adaptive Cruise Control)																																													
300	2014	AMP (Audio)																						V	V																							
300	2014	DDM (Drivers Door Module)																					V																									
300	2014	DTCM (Drive Train Control Module)																																													
300	2014	ESM (Electronic Shifter Module)																																													
300	2014	HFM (Hands Free Module)																																								V					
300	2014	HSM (Heated Seat Module)																																													
300	2014	HVAC (Heat Vent A/C)																								V	V	V	V																		
300	2014	ITM (Intrusion)																																													
300	2014	ORC (Occupant Restraint Control)		V																																											

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
300	2014	PDM (Passenger Door Module)																																													
300	2014	PTS (Park Assist Module)																																													
300	2014	TCM (Transmission Control Module)																																													
300	2014	TPM (Tire Pressure Monitor)																																													
300	2013	PCM (Powertrain Control Module)																																													
300	2013	ABS (Anti Lock Brake System)	V																																												
300	2013	ACC (Adaptive Cruise Control)																																													
300	2013	AMP (Audio)																						V	V																						
300	2013	DDM (Drivers Door Module)																					V																								
300	2013	DTCM (Drive Train Control Module)																																													
300	2013	ESM (Electronic Shifter Module)																																													
300	2013	HFM (Hands Free Module)																																								V					
300	2013	HSM (Heated Seat Module)																																													
300	2013	HVAC (Heat Vent A/C)																								V	V	V	V																		
300	2013	ITM (Intrusion)																																													
300	2013	ORC (Occupant Restraint Control)		V																																											
300	2013	PDM (Passenger Door Module)																																													
300	2013	PTS (Park Assist Module)																																													
300	2013	TCM (Transmission Control Module)																																													
300	2013	TPM (Tire Pressure Monitor)																																													
300	2012	PCM (Powertrain Control Module)																																													
300	2012	ABS (Anti Lock Brake System)	V																																												
300	2012	ACC (Adaptive Cruise Control)																																													
300	2012	AMP (Audio)																						V	V																						
300	2012	DDM (Drivers Door Module)																					V																								
300	2012	DTCM (Drive Train Control Module)																																													
300	2012	ESM (Electronic Shifter Module)																																													
300	2012	HFM (Hands Free Module)																																								V					
300	2012	HSM (Heated Seat Module)																																													
300	2012	HVAC (Heat Vent A/C)																								V	V	V	V																		
300	2012	ITM (Intrusion)																																													
300	2012	ORC (Occupant Restraint Control)		V																																											
300	2012	PDM (Passenger Door Module)																																													
300	2012	PTS (Park Assist Module)																																													
300	2012	TCM (Transmission Control Module)																																													
300	2012	TPM (Tire Pressure Monitor)																																													
300	2011	PCM (Powertrain Control Module)																																													
300	2011	ABS (Anti Lock Brake System)	V																																												
300	2011	ACC (Adaptive Cruise Control)																																													
300	2011	AMP (Audio)																						V	V																						
300	2011	DDM (Drivers Door Module)																					V																								
300	2011	DTCM (Drive Train Control Module)																																													

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
300	2011	ESM (Electronic Shifter Module)																																														
300	2011	HFM (Hands Free Module)																																							V							
300	2011	HSM (Heated Seat Module)																																														
300	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
300	2011	ORC (Occupant Restraint Control)		V																																												
300	2011	PDM (Passenger Door Module)																																														
300	2011	PTS (Park Assist Module)																																														
300	2011	TCM (Transmission Control Module)																																														
300	2011	TPM (Tire Pressure Monitor)																																														
300	2010	PCM (Powertrain Control Module)																																														
300	2010	ABS (Anti Lock Brake System)	V																																													
300	2010	ACC (Adaptive Cruise Control)																																														
300	2010	AHBM (Automatic High Beam)																																														
300	2010	AMP (Audio)																						V	V																							
300	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
300	2010	DDM (Drivers Door Module)																					V																									
300	2010	DTCM (Drive Train Control Module)																																														
300	2010	EOM (Electric Overhead Module)																																											V			
300	2010	ESM (Electronic Shifter Module)																																														
300	2010	HFM (Hands Free Module)																																							V							
300	2010	HSM (Heated Seat Module)																																														
300	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
300	2010	ITM (Intrusion)																																														
300	2010	LRSM (Light Rain Sensor Module)																																														
300	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
300	2010	ORC (Occupant Restraint Control)		V																																												
300	2010	PDM (Passenger Door Module)																																														
300	2010	PTS (Park Assist Module)																																														
300	2010	RADIO (Radio)																																				V	V	V	V							
300	2010	SCM (Steering Column Module)																																														
300	2010	SUNR (Sunroof Module)																																														
300	2010	TCM (Transmission Control Module)																																														
300	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
300	2010	TPM (Tire Pressure Monitor)																																														
300	2010	VES3 (Vidio Entertainment System 3)																																														
300	2010	WCM(Wireless Control Modules)														V																											V	V				
300	2009	PCM (Powertrain Control Module)																																														
300	2009	ABS (Anti Lock Brake System)	V																																													
300	2009	ACC (Adaptive Cruise Control)																																														
300	2009	AHBM (Automatic High Beam)																																														
300	2009	AMP (Audio)																						V	V																							
300	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
300	2009	DDM (Drivers Door Module)																					V																									
300	2009	DTCM (Drive Train Control Module)																																														
300	2009	EOM (Electric Overhead Module)																																											V			
300	2009	ESM (Electronic Shifter Module)																																														
300	2009	HFM (Hands Free Module)																																								V						
300	2009	HSM (Heated Seat Module)																																														
300	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
300	2009	ITM (Intrusion)																																														
300	2009	LRSM (Light Rain Sensor Module)																																														
300	2009	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
300	2009	ORC (Occupant Restraint Control)		V																																												
300	2009	PDM (Passenger Door Module)																																														
300	2009	PTS (Park Assist Module)																																														
300	2009	RADIO (Radio)																																				V	V	V	V							
300	2009	SCM (Steering Column Module)																																														
300	2009	SUNR (Sunroof Module)																																														
300	2009	TCM (Transmission Control Module)																																														
300	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
300	2009	TPM (Tire Pressure Monitor)																																														
300	2009	VES3 (Vidio Entertainment System 3)																																														
300	2009	WCM(Wireless Control Modules)														V																											V	V				
300	2008	PCM (Powertrain Control Module)																																														
300	2008	ABS (Anti Lock Brake System)	V																																													
300	2008	ACC (Adaptive Cruise Control)																																														
300	2008	AHBM (Automatic High Beam)																																														
300	2008	AMP (Audio)																						V	V																							
300	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
300	2008	DDM (Drivers Door Module)																					V																									
300	2008	EOM (Electric Overhead Module)																																											V			
300	2008	ESM (Electronic Shifter Module)																																														
300	2008	HFM (Hands Free Module)																																								V						
300	2008	HSM (Heated Seat Module)																																														
300	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
300	2008	ITM (Intrusion)																																														
300	2008	LRSM (Light Rain Sensor Module)																																														
300	2008	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
300	2008	ORC (Occupant Restraint Control)		V																																												
300	2008	PDM (Passenger Door Module)																																														
300	2008	PTS (Park Assist Module)																																														
300	2008	RADIO (Radio)																																				V	V	V	V							
300	2008	SCM (Steering Column Module)																																														
300	2008	SUNR (Sunroof Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
300	2008	TCM (Transmission Control Module)																																														
300	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
300	2008	VES3 (Vidio Entertainment System 3)																																														
300	2008	WCM(Wireless Control Modules)														V																											V	V				
300	2007	PCM (Powertrain Control Module)																																														
300	2007	ABS (Anti Lock Brake System)	V																																													
300	2007	ACC (Adaptive Cruise Control)																																														
300	2007	AHBM (Automatic High Beam)																																														
300	2007	AMP (Audio)																						V	V																							
300	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
300	2007	DDM (Drivers Door Module)																					V																									
300	2007	EOM (Electric Overhead Module)																																											V			
300	2007	ESM (Electronic Shifter Module)																																														
300	2007	HFM (Hands Free Module)																																								V						
300	2007	HSM (Heated Seat Module)																																														
300	2007	HVAC (Heat Vent A/C)																								V	V	V	V																			
300	2007	ITM (Intrusion)																																														
300	2007	LRSM (Light Rain Sensor Module)																																														
300	2007	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
300	2007	ORC (Occupant Restraint Control)		V																																												
300	2007	PDM (Passenger Door Module)																																														
300	2007	PTS (Park Assist Module)																																														
300	2007	RADIO (Radio)																																				V	V	V	V							
300	2007	SCM (Steering Column Module)																																														
300	2007	SDAR (Satellite Radio)																																														
300	2007	SUNR (Sunroof Module)																																														
300	2007	TCM (Transmission Control Module)																																														
300	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
300	2007	WCM(Wireless Control Modules)														V																											V	V				
300	2006	PCM (Powertrain Control Module)																																														
300	2006	ABS (Anti Lock Brake System)	V																																													
300	2006	AHBM (Automatic High Beam)																																														
300	2006	AMP (Audio)																						V	V																							
300	2006	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
300	2006	DDM (Drivers Door Module)																					V																									
300	2006	EOM (Electric Overhead Module)																																											V			
300	2006	ESM (Electronic Shifter Module)																																														
300	2006	HFM (Hands Free Module)																																								V						
300	2006	HSM (Heated Seat Module)																																														
300	2006	HVAC (Heat Vent A/C)																								V	V	V	V																			
300	2006	ITM (Intrusion)																																														
300	2006	LRSM (Light Rain Sensor Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
300	2006	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
300	2006	OCM (Occupant Classification Module)																																														
300	2006	ORC (Occupant Restraint Control)		V																																												
300	2006	PDM (Passenger Door Module)																																														
300	2006	PTS (Park Assist Module)																																														
300	2006	RADIO (Radio)																																				V	V	V	V						
300	2006	SCM (Steering Column Module)																																														
300	2006	SDAR (Satellite Radio)																																														
300	2006	SUNR (Sunroof Module)																																														
300	2006	TCM (Transmission Control Module)																																														
300	2006	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
300	2006	WCM(Wireless Control Modules)														V																											V	V				
300	2005	PCM (Powertrain Control Module)																																														
300	2005	ABS (Anti Lock Brake System)	V																																													
300	2005	AMP (Audio)																						V	V																							
300	2005	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
300	2005	DDM (Drivers Door Module)																					V																									
300	2005	EOM (Electric Overhead Module)																																											V			
300	2005	ESM (Electronic Shifter Module)																																														
300	2005	HFM (Hands Free Module)																																								V						
300	2005	HSM (Heated Seat Module)																																														
300	2005	HVAC (Heat Vent A/C)																								V	V	V	V																			
300	2005	LRSM (Light Rain Sensor Module)																																														
300	2005	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
300	2005	OCM (Occupant Classification Module)																																														
300	2005	ORC (Occupant Restraint Control)		V																																												
300	2005	PDM (Passenger Door Module)																																														
300	2005	PTS (Park Assist Module)																																														
300	2005	RADIO (Radio)																																				V	V	V	V						
300	2005	SCM (Steering Column Module)																																														
300	2005	SDAR (Satellite Radio)																																														
300	2005	SUNR (Sunroof Module)																																														
300	2005	TCM (Transmission Control Module)																																														
300	2005	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
300	2005	WCM(Wireless Control Modules)														V																											V	V				
ASPEN	2009	PCM (Powertrain Control Module)																																														
ASPEN	2009	ABS (Anti Lock Brake System)	V																																													
ASPEN	2009	AMP (Audio)																						V	V																							
ASPEN	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
ASPEN	2009	DDM (Drivers Door Module)																					V																									
ASPEN	2009	EOM (Electric Overhead Module)																																											V			
ASPEN	2009	HFM (Hands Free Module)																																								V						

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
ASPEN	2009	HSM (Heated Seat Module)																																														
ASPEN	2009	HVAC (Heat Vent A/C)																								V	V	V	V																		
ASPEN	2009	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V										
ASPEN	2009	ORC (Occupant Restraint Control)		V																																											
ASPEN	2009	PDM (Passenger Door Module)																																													
ASPEN	2009	PLM (Power Liftgate Module)																																													
ASPEN	2009	PTS (Park Assist Module)																																													
ASPEN	2009	RADIO (Radio)																																				V	V	V	V						
ASPEN	2009	SAS (Steering Angle Sensor)																																													
ASPEN	2009	TCM (Transmission Control Module)																																													
ASPEN	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
ASPEN	2009	VES3 (Vidio Entertainment System 3)																																													
ASPEN	2009	WCM(Wireless Control Modules)														V																											V	V			
ASPEN	2008	PCM (Powertrain Control Module)																																													
ASPEN	2008	ABS (Anti Lock Brake System)	V																																												
ASPEN	2008	AMP (Audio)																						V	V																						
ASPEN	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
ASPEN	2008	DDM (Drivers Door Module)																					V																								
ASPEN	2008	EOM (Electric Overhead Module)																																											V		
ASPEN	2008	HFM (Hands Free Module)																																								V					
ASPEN	2008	HSM (Heated Seat Module)																																													
ASPEN	2008	HVAC (Heat Vent A/C)																								V	V	V	V																		
ASPEN	2008	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V										
ASPEN	2008	ORC (Occupant Restraint Control)		V																																											
ASPEN	2008	PDM (Passenger Door Module)																																													
ASPEN	2008	PLM (Power Liftgate Module)																																													
ASPEN	2008	PTS (Park Assist Module)																																													
ASPEN	2008	RADIO (Radio)																																				V	V	V	V						
ASPEN	2008	SAS (Steering Angle Sensor)																																													
ASPEN	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
ASPEN	2008	VES3 (Vidio Entertainment System 3)																																													
ASPEN	2008	WCM(Wireless Control Modules)														V																											V	V			
ASPEN	2007	PCM (Powertrain Control Module)																																													
ASPEN	2007	ABS (Anti Lock Brake System)	V																																												
ASPEN	2007	AMP (Audio)																						V	V																						
ASPEN	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
ASPEN	2007	DDM (Drivers Door Module)																					V																								
ASPEN	2007	EOM (Electric Overhead Module)																																											V		
ASPEN	2007	HFM (Hands Free Module)																																								V					
ASPEN	2007	HSM (Heated Seat Module)																																													
ASPEN	2007	HVAC (Heat Vent A/C)																								V	V	V	V																		
ASPEN	2007	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V										

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
ASPEN	2007	ORC (Occupant Restraint Control)		V																																												
ASPEN	2007	PDM (Passenger Door Module)																																														
ASPEN	2007	PLM (Power Liftgate Module)																																														
ASPEN	2007	PTS (Park Assist Module)																																														
ASPEN	2007	RADIO (Radio)																																				V	V	V	V						
ASPEN	2007	SAS (Steering Angle Sensor)																																														
ASPEN	2007	SDAR (Satellite Radio)																																														
ASPEN	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
ASPEN	2007	WCM(Wireless Control Modules)														V																											V	V				
GRAND VOYAGER	2016	PCM (Powertrain Control Module)																																														
GRAND VOYAGER	2016	ABS (Anti Lock Brake System)																																														
GRAND VOYAGER	2016	AHBM (Automatic High Beam)																																														
GRAND VOYAGER	2016	AMP (Audio)																																														
GRAND VOYAGER	2016	BCM (Body Control Module)																																														
GRAND VOYAGER	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
GRAND VOYAGER	2016	CGW (Central Gateway)																																														
GRAND VOYAGER	2016	HFM (Hands Free Module)																																														
GRAND VOYAGER	2016	HVAC (Heat Vent A/C)																																														
GRAND VOYAGER	2016	IPC (Instrument Panel Cluster)																																														
GRAND VOYAGER	2016	ITM (Intrusion)																																														
GRAND VOYAGER	2016	LBSS (Left Blind Spot Sensor)																																														
GRAND VOYAGER	2016	MSMD (Memory Seet Module)																																														
GRAND VOYAGER	2016	ORC (Occupant Restraint Control)																																														
GRAND VOYAGER	2016	PTS (Park Assist Module)																																														
GRAND VOYAGER	2016	RADIO (Radio)																																														
GRAND VOYAGER	2016	RBSS (Right Blind Spot Sensor)																																														
GRAND VOYAGER	2016	RFH (Radio Frequency Hub)																																														
GRAND VOYAGER	2016	SAS (Steering Angle Sensor)																																														
GRAND VOYAGER	2016	SUNR (Sunroof Module)																																														
GRAND VOYAGER	2016	TCM (Transmission Control Module)																																														
GRAND VOYAGER	2016	TPM (Tire Pressure Monitor)																																														
GRAND VOYAGER	2016	VES3 (Vidio Entertainment System 3)																																														
GRAND VOYAGER	2016	WCM(Wireless Control Modules)																																														
GRAND VOYAGER	2015	PCM (Powertrain Control Module)																																														
GRAND VOYAGER	2015	ABS (Anti Lock Brake System)																																														
GRAND VOYAGER	2015	AHBM (Automatic High Beam)																																														
GRAND VOYAGER	2015	AMP (Audio)																																														
GRAND VOYAGER	2015	BCM (Body Control Module)																																														
GRAND VOYAGER	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
GRAND VOYAGER	2015	CGW (Central Gateway)																																														
GRAND VOYAGER	2015	HFM (Hands Free Module)																																														
GRAND VOYAGER	2015	HVAC (Heat Vent A/C)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND VOYAGER	2015	IPC (Instrument Panel Cluster)																																														
GRAND VOYAGER	2015	ITM (Intrusion)																																														
GRAND VOYAGER	2015	LBSS (Left Blind Spot Sensor)																																														
GRAND VOYAGER	2015	MSMD (Memory Seet Module)																																														
GRAND VOYAGER	2015	ORC (Occupant Restraint Control)																																														
GRAND VOYAGER	2015	PTS (Park Assist Module)																																														
GRAND VOYAGER	2015	RADIO (Radio)																																														
GRAND VOYAGER	2015	RBSS (Right Blind Spot Sensor)																																														
GRAND VOYAGER	2015	RFH (Radio Frequency Hub)																																														
GRAND VOYAGER	2015	SAS (Steering Angle Sensor)																																														
GRAND VOYAGER	2015	SUNR (Sunroof Module)																																														
GRAND VOYAGER	2015	TCM (Transmission Control Module)																																														
GRAND VOYAGER	2015	TPM (Tire Pressure Monitor)																																														
GRAND VOYAGER	2015	VES3 (Vidio Entertainment System 3)																																														
GRAND VOYAGER	2015	WCM(Wireless Control Modules)																																														
GRAND VOYAGER	2014	PCM (Powertrain Control Module)																																														
GRAND VOYAGER	2014	ABS (Anti Lock Brake System)	V																																													
GRAND VOYAGER	2014	AHBM (Automatic High Beam)																																														
GRAND VOYAGER	2014	AMP (Audio)																						V	V																							
GRAND VOYAGER	2014	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND VOYAGER	2014	HFM (Hands Free Module)																																								V						
GRAND VOYAGER	2014	HSM (Heated Seat Module)																																														
GRAND VOYAGER	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND VOYAGER	2014	ITM (Intrusion)																																														
GRAND VOYAGER	2014	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND VOYAGER	2014	ORC (Occupant Restraint Control)		V																																												
GRAND VOYAGER	2014	PLM (Power Liftgate Module)																																														
GRAND VOYAGER	2014	PTS (Park Assist Module)																																														
GRAND VOYAGER	2014	RADIO (Radio)																																				V	V	V	V							
GRAND VOYAGER	2014	SAS (Steering Angle Sensor)																																														
GRAND VOYAGER	2014	SUNR (Sunroof Module)																																														
GRAND VOYAGER	2014	TCM (Transmission Control Module)																																														
GRAND VOYAGER	2014	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
GRAND VOYAGER	2014	TPM (Tire Pressure Monitor)																																														
GRAND VOYAGER	2014	VES3 (Vidio Entertainment System 3)																																														
GRAND VOYAGER	2014	WCM(Wireless Control Modules)														V																											V	V				
GRAND VOYAGER	2013	PCM (Powertrain Control Module)																																														
GRAND VOYAGER	2013	ABS (Anti Lock Brake System)	V																																													
GRAND VOYAGER	2013	AHBM (Automatic High Beam)																																														
GRAND VOYAGER	2013	AMP (Audio)																						V	V																							
GRAND VOYAGER	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND VOYAGER	2013	HFM (Hands Free Module)																																								V						

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND VOYAGER	2013	HSM (Heated Seat Module)																																														
GRAND VOYAGER	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND VOYAGER	2013	ITM (Intrusion)																																														
GRAND VOYAGER	2013	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND VOYAGER	2013	ORC (Occupant Restraint Control)		V																																												
GRAND VOYAGER	2013	PLM (Power Liftgate Module)																																														
GRAND VOYAGER	2013	PTS (Park Assist Module)																																														
GRAND VOYAGER	2013	RADIO (Radio)																																				V	V	V	V							
GRAND VOYAGER	2013	SAS (Steering Angle Sensor)																																														
GRAND VOYAGER	2013	SUNR (Sunroof Module)																																														
GRAND VOYAGER	2013	TCM (Transmission Control Module)																																														
GRAND VOYAGER	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND VOYAGER	2013	TPM (Tire Pressure Monitor)																																														
GRAND VOYAGER	2013	VES3 (Vidio Entertainment System 3)																																														
GRAND VOYAGER	2013	WCM(Wireless Control Modules)														V																											V	V				
GRAND VOYAGER	2012	PCM (Powertrain Control Module)																																														
GRAND VOYAGER	2012	ABS (Anti Lock Brake System)	V																																													
GRAND VOYAGER	2012	AHBM (Automatic High Beam)																																														
GRAND VOYAGER	2012	AMP (Audio)																						V	V																							
GRAND VOYAGER	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND VOYAGER	2012	HFM (Hands Free Module)																																								V						
GRAND VOYAGER	2012	HSM (Heated Seat Module)																																														
GRAND VOYAGER	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND VOYAGER	2012	ITM (Intrusion)																																														
GRAND VOYAGER	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND VOYAGER	2012	ORC (Occupant Restraint Control)		V																																												
GRAND VOYAGER	2012	PLM (Power Liftgate Module)																																														
GRAND VOYAGER	2012	PTS (Park Assist Module)																																														
GRAND VOYAGER	2012	RADIO (Radio)																																				V	V	V	V							
GRAND VOYAGER	2012	SAS (Steering Angle Sensor)																																														
GRAND VOYAGER	2012	SUNR (Sunroof Module)																																														
GRAND VOYAGER	2012	TCM (Transmission Control Module)																																														
GRAND VOYAGER	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND VOYAGER	2012	TPM (Tire Pressure Monitor)																																														
GRAND VOYAGER	2012	VES3 (Vidio Entertainment System 3)																																														
GRAND VOYAGER	2012	WCM(Wireless Control Modules)														V																											V	V				
GRAND VOYAGER	2011	PCM (Powertrain Control Module)																																														
GRAND VOYAGER	2011	ABS (Anti Lock Brake System)	V																																													
GRAND VOYAGER	2011	AHBM (Automatic High Beam)																																														
GRAND VOYAGER	2011	AMP (Audio)																						V	V																							
GRAND VOYAGER	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND VOYAGER	2011	HFM (Hands Free Module)																																								V						

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND VOYAGER	2011	HSM (Heated Seat Module)																																														
GRAND VOYAGER	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND VOYAGER	2011	ITM (Intrusion)																																														
GRAND VOYAGER	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND VOYAGER	2011	ORC (Occupant Restraint Control)		V																																												
GRAND VOYAGER	2011	PLM (Power Liftgate Module)																																														
GRAND VOYAGER	2011	PTS (Park Assist Module)																																														
GRAND VOYAGER	2011	RADIO (Radio)																																				V	V	V	V							
GRAND VOYAGER	2011	SAS (Steering Angle Sensor)																																														
GRAND VOYAGER	2011	SUNR (Sunroof Module)																																														
GRAND VOYAGER	2011	TCM (Transmission Control Module)																																														
GRAND VOYAGER	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND VOYAGER	2011	TPM (Tire Pressure Monitor)																																														
GRAND VOYAGER	2011	VES3 (Vidio Entertainment System 3)																																														
GRAND VOYAGER	2011	WCM(Wireless Control Modules)														V																											V	V				
GRAND VOYAGER	2010	PCM (Powertrain Control Module)																																														
GRAND VOYAGER	2010	ABS (Anti Lock Brake System)	V																																													
GRAND VOYAGER	2010	AHBM (Automatic High Beam)																																														
GRAND VOYAGER	2010	AMP (Audio)																						V	V																							
GRAND VOYAGER	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND VOYAGER	2010	HFM (Hands Free Module)																																								V						
GRAND VOYAGER	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND VOYAGER	2010	ITM (Intrusion)																																														
GRAND VOYAGER	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND VOYAGER	2010	ORC (Occupant Restraint Control)		V																																												
GRAND VOYAGER	2010	PLM (Power Liftgate Module)																																														
GRAND VOYAGER	2010	PTS (Park Assist Module)																																														
GRAND VOYAGER	2010	RADIO (Radio)																																				V	V	V	V							
GRAND VOYAGER	2010	SAS (Steering Angle Sensor)																																														
GRAND VOYAGER	2010	SUNR (Sunroof Module)																																														
GRAND VOYAGER	2010	TCM (Transmission Control Module)																																														
GRAND VOYAGER	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND VOYAGER	2010	VES3 (Vidio Entertainment System 3)																																														
GRAND VOYAGER	2010	WCM(Wireless Control Modules)														V																											V	V				
GRAND VOYAGER	2009	PCM (Powertrain Control Module)																																														
GRAND VOYAGER	2009	ABS (Anti Lock Brake System)	V																																													
GRAND VOYAGER	2009	AHBM (Automatic High Beam)																																														
GRAND VOYAGER	2009	AMP (Audio)																						V	V																							
GRAND VOYAGER	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND VOYAGER	2009	HFM (Hands Free Module)																																								V						
GRAND VOYAGER	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND VOYAGER	2009	ITM (Intrusion)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND VOYAGER	2009	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND VOYAGER	2009	ORC (Occupant Restraint Control)		V																																												
GRAND VOYAGER	2009	PLM (Power Liftgate Module)																																														
GRAND VOYAGER	2009	PTS (Park Assist Module)																																														
GRAND VOYAGER	2009	RADIO (Radio)																																				V	V	V	V							
GRAND VOYAGER	2009	SAS (Steering Angle Sensor)																																														
GRAND VOYAGER	2009	SUNR (Sunroof Module)																																														
GRAND VOYAGER	2009	TCM (Transmission Control Module)																																														
GRAND VOYAGER	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND VOYAGER	2009	VES3 (Vidio Entertainment System 3)																																														
GRAND VOYAGER	2009	WCM(Wireless Control Modules)														V																												V	V			
GRAND VOYAGER	2008	PCM (Powertrain Control Module)																																														
GRAND VOYAGER	2008	ABS (Anti Lock Brake System)	V																																													
GRAND VOYAGER	2008	AHBM (Automatic High Beam)																																														
GRAND VOYAGER	2008	AMP (Audio)																						V	V																							
GRAND VOYAGER	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND VOYAGER	2008	HFM (Hands Free Module)																																								V						
GRAND VOYAGER	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND VOYAGER	2008	ITM (Intrusion)																																														
GRAND VOYAGER	2008	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND VOYAGER	2008	ORC (Occupant Restraint Control)		V																																												
GRAND VOYAGER	2008	PLM (Power Liftgate Module)																																														
GRAND VOYAGER	2008	PTS (Park Assist Module)																																														
GRAND VOYAGER	2008	RADIO (Radio)																																				V	V	V	V							
GRAND VOYAGER	2008	SAS (Steering Angle Sensor)																																														
GRAND VOYAGER	2008	SUNR (Sunroof Module)																																														
GRAND VOYAGER	2008	TCM (Transmission Control Module)																																														
GRAND VOYAGER	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND VOYAGER	2008	VES3 (Vidio Entertainment System 3)																																														
GRAND VOYAGER	2008	WCM(Wireless Control Modules)														V																												V	V			
PACIFICA	2008	PCM (Powertrain Control Module)																																														
PACIFICA	2008	ABS (Anti Lock Brake System)	V																																													
PACIFICA	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
PACIFICA	2008	ORC (Occupant Restraint Control)		V																																												
PACIFICA	2008	PLM (Power Liftgate Module)																																														
PACIFICA	2008	SAS (Steering Angle Sensor)																																														
PACIFICA	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
PACIFICA	2007	PCM (Powertrain Control Module)																																														
PACIFICA	2007	ABS (Anti Lock Brake System)	V																																													
PACIFICA	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
PACIFICA	2007	ORC (Occupant Restraint Control)		V																																												
PACIFICA	2007	PLM (Power Liftgate Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
PACIFICA	2007	SAS (Steering Angle Sensor)																																														
PACIFICA	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
PT CRUISER	2010	PCM (Powertrain Control Module)																																														
PT CRUISER	2010	ABS (Anti Lock Brake System)	V																																													
PT CRUISER	2010	AMP (Audio)																						V	V																							
PT CRUISER	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
PT CRUISER	2010	DDM (Drivers Door Module)																					V																									
PT CRUISER	2010	HFM (Hands Free Module)																																							V							
PT CRUISER	2010	ITM (Intrusion)																																														
PT CRUISER	2010	OCM (Occupant Classification Module)																																														
PT CRUISER	2010	ORC (Occupant Restraint Control)		V																																												
PT CRUISER	2010	PDM (Passenger Door Module)																																														
PT CRUISER	2010	RADIO (Radio)																																				V	V	V	V							
PT CRUISER	2010	SDAR (Satellite Radio)																																														
PT CRUISER	2010	TCM (Transmission Control Module)																																														
PT CRUISER	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
PT CRUISER	2010	WCM(Wireless Control Modules)														V																											V	V				
PT CRUISER	2009	PCM (Powertrain Control Module)																																														
PT CRUISER	2009	ABS (Anti Lock Brake System)	V																																													
PT CRUISER	2009	AMP (Audio)																						V	V																							
PT CRUISER	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
PT CRUISER	2009	DDM (Drivers Door Module)																					V																									
PT CRUISER	2009	HFM (Hands Free Module)																																							V							
PT CRUISER	2009	ITM (Intrusion)																																														
PT CRUISER	2009	OCM (Occupant Classification Module)																																														
PT CRUISER	2009	ORC (Occupant Restraint Control)		V																																												
PT CRUISER	2009	PDM (Passenger Door Module)																																														
PT CRUISER	2009	RADIO (Radio)																																				V	V	V	V							
PT CRUISER	2009	SDAR (Satellite Radio)																																														
PT CRUISER	2009	TCM (Transmission Control Module)																																														
PT CRUISER	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
PT CRUISER	2009	WCM(Wireless Control Modules)														V																											V	V				
PT CRUISER	2008	PCM (Powertrain Control Module)																																														
PT CRUISER	2008	ABS (Anti Lock Brake System)	V																																													
PT CRUISER	2008	AMP (Audio)																						V	V																							
PT CRUISER	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
PT CRUISER	2008	DDM (Drivers Door Module)																					V																									
PT CRUISER	2008	HFM (Hands Free Module)																																							V							
PT CRUISER	2008	ITM (Intrusion)																																														
PT CRUISER	2008	OCM (Occupant Classification Module)																																														
PT CRUISER	2008	ORC (Occupant Restraint Control)		V																																												
PT CRUISER	2008	PDM (Passenger Door Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
PT CRUISER	2008	RADIO (Radio)																																				V	V	V	V						
PT CRUISER	2008	SDAR (Satellite Radio)																																														
PT CRUISER	2008	TCM (Transmission Control Module)																																														
PT CRUISER	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
PT CRUISER	2008	WCM(Wireless Control Modules)														V																											V	V				
PT CRUISER	2007	PCM (Powertrain Control Module)																																														
PT CRUISER	2007	ABS (Anti Lock Brake System)	V																																													
PT CRUISER	2007	AMP (Audio)																						V	V																							
PT CRUISER	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
PT CRUISER	2007	DDM (Drivers Door Module)																					V																									
PT CRUISER	2007	HFM (Hands Free Module)																																								V						
PT CRUISER	2007	ITM (Intrusion)																																														
PT CRUISER	2007	OCM (Occupant Classification Module)																																														
PT CRUISER	2007	ORC (Occupant Restraint Control)		V																																												
PT CRUISER	2007	PDM (Passenger Door Module)																																														
PT CRUISER	2007	RADIO (Radio)																																				V	V	V	V						
PT CRUISER	2007	SDAR (Satellite Radio)																																														
PT CRUISER	2007	TCM (Transmission Control Module)																																														
PT CRUISER	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
PT CRUISER	2007	WCM(Wireless Control Modules)														V																											V	V				
PT CRUISER	2006	PCM (Powertrain Control Module)																																														
PT CRUISER	2006	ABS (Anti Lock Brake System)	V																																													
PT CRUISER	2006	AMP (Audio)																						V	V																							
PT CRUISER	2006	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
PT CRUISER	2006	DDM (Drivers Door Module)																					V																									
PT CRUISER	2006	HFM (Hands Free Module)																																								V						
PT CRUISER	2006	ITM (Intrusion)																																														
PT CRUISER	2006	OCM (Occupant Classification Module)																																														
PT CRUISER	2006	ORC (Occupant Restraint Control)		V																																												
PT CRUISER	2006	PDM (Passenger Door Module)																																														
PT CRUISER	2006	RADIO (Radio)																																				V	V	V	V						
PT CRUISER	2006	SDAR (Satellite Radio)																																														
PT CRUISER	2006	TCM (Transmission Control Module)																																														
PT CRUISER	2006	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
PT CRUISER	2006	WCM(Wireless Control Modules)														V																											V	V				
SEBRING	2014	PCM (Powertrain Control Module)																																														
SEBRING	2014	ABS (Anti Lock Brake System)	V																																													
SEBRING	2014	AMP (Audio)																						V	V																							
SEBRING	2014	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
SEBRING	2014	DDM (Drivers Door Module)																					V																									
SEBRING	2014	HFM (Hands Free Module)																																								V						
SEBRING	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
SEBRING	2014	ORC (Occupant Restraint Control)		V																																												
SEBRING	2014	PDM (Passenger Door Module)																																														
SEBRING	2014	RADIO (Radio)																																				V	V	V	V						
SEBRING	2014	SAS (Steering Angle Sensor)																																														
SEBRING	2014	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
SEBRING	2014	WCM(Wireless Control Modules)														V																											V	V				
SEBRING	2013	PCM (Powertrain Control Module)																																														
SEBRING	2013	ABS (Anti Lock Brake System)	V																																													
SEBRING	2013	AMP (Audio)																						V	V																							
SEBRING	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
SEBRING	2013	DDM (Drivers Door Module)																					V																									
SEBRING	2013	HFM (Hands Free Module)																																								V						
SEBRING	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
SEBRING	2013	ORC (Occupant Restraint Control)		V																																												
SEBRING	2013	PDM (Passenger Door Module)																																														
SEBRING	2013	RADIO (Radio)																																				V	V	V	V						
SEBRING	2013	SAS (Steering Angle Sensor)																																														
SEBRING	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
SEBRING	2013	WCM(Wireless Control Modules)														V																											V	V				
SEBRING	2012	PCM (Powertrain Control Module)																																														
SEBRING	2012	ABS (Anti Lock Brake System)	V																																													
SEBRING	2012	AMP (Audio)																						V	V																							
SEBRING	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
SEBRING	2012	DDM (Drivers Door Module)																					V																									
SEBRING	2012	HFM (Hands Free Module)																																								V						
SEBRING	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
SEBRING	2012	ORC (Occupant Restraint Control)		V																																												
SEBRING	2012	PDM (Passenger Door Module)																																														
SEBRING	2012	RADIO (Radio)																																				V	V	V	V						
SEBRING	2012	SAS (Steering Angle Sensor)																																														
SEBRING	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
SEBRING	2012	WCM(Wireless Control Modules)														V																											V	V				
SEBRING	2011	PCM (Powertrain Control Module)																																														
SEBRING	2011	ABS (Anti Lock Brake System)	V																																													
SEBRING	2011	AMP (Audio)																						V	V																							
SEBRING	2011	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
SEBRING	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
SEBRING	2011	DDM (Drivers Door Module)																					V																									
SEBRING	2011	ESM (Electronic Shifter Module)																																														
SEBRING	2011	HFM (Hands Free Module)																																								V						
SEBRING	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
SEBRING	2011	ITM (Intrusion)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
SEBRING	2011	ORC (Occupant Restraint Control)		V																																												
SEBRING	2011	PDM (Passenger Door Module)																																														
SEBRING	2011	RADIO (Radio)																																				V	V	V	V						
SEBRING	2011	SAS (Steering Angle Sensor)																																														
SEBRING	2011	TCM (Transmission Control Module)																																														
SEBRING	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
SEBRING	2011	VES3 (Vidio Entertainment System 3)																																														
SEBRING	2011	WCM(Wireless Control Modules)														V																											V	V				
SEBRING	2010	PCM (Powertrain Control Module)																																														
SEBRING	2010	ABS (Anti Lock Brake System)	V																																													
SEBRING	2010	AMP (Audio)																						V	V																							
SEBRING	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
SEBRING	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
SEBRING	2010	DDM (Drivers Door Module)																					V																									
SEBRING	2010	HFM (Hands Free Module)																																								V						
SEBRING	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
SEBRING	2010	ITM (Intrusion)																																														
SEBRING	2010	ORC (Occupant Restraint Control)		V																																												
SEBRING	2010	PDM (Passenger Door Module)																																														
SEBRING	2010	RADIO (Radio)																																				V	V	V	V						
SEBRING	2010	SAS (Steering Angle Sensor)																																														
SEBRING	2010	TCM (Transmission Control Module)																																														
SEBRING	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
SEBRING	2010	VES3 (Vidio Entertainment System 3)																																														
SEBRING	2010	WCM(Wireless Control Modules)														V																											V	V				
SEBRING	2009	PCM (Powertrain Control Module)																																														
SEBRING	2009	ABS (Anti Lock Brake System)	V																																													
SEBRING	2009	AMP (Audio)																						V	V																							
SEBRING	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
SEBRING	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
SEBRING	2009	DDM (Drivers Door Module)																					V																									
SEBRING	2009	HFM (Hands Free Module)																																								V						
SEBRING	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
SEBRING	2009	ITM (Intrusion)																																														
SEBRING	2009	ORC (Occupant Restraint Control)		V																																												
SEBRING	2009	PDM (Passenger Door Module)																																														
SEBRING	2009	RADIO (Radio)																																				V	V	V	V						
SEBRING	2009	SAS (Steering Angle Sensor)																																														
SEBRING	2009	TCM (Transmission Control Module)																																														
SEBRING	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
SEBRING	2009	VES3 (Vidio Entertainment System 3)																																														
SEBRING	2009	WCM(Wireless Control Modules)														V																											V	V				

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
SEBRING	2008	PCM (Powertrain Control Module)																																														
SEBRING	2008	ABS (Anti Lock Brake System)	V																																													
SEBRING	2008	AMP (Audio)																						V	V																							
SEBRING	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
SEBRING	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
SEBRING	2008	DDM (Drivers Door Module)																					V																									
SEBRING	2008	HFM (Hands Free Module)																																								V						
SEBRING	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
SEBRING	2008	ITM (Intrusion)																																														
SEBRING	2008	ORC (Occupant Restraint Control)		V																																												
SEBRING	2008	PDM (Passenger Door Module)																																														
SEBRING	2008	RADIO (Radio)																																				V	V	V	V							
SEBRING	2008	SAS (Steering Angle Sensor)																																														
SEBRING	2008	TCM (Transmission Control Module)																																														
SEBRING	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
SEBRING	2008	VES3 (Vidio Entertainment System 3)																																														
SEBRING	2008	WCM(Wireless Control Modules)														V																											V	V				
SEBRING	2007	PCM (Powertrain Control Module)																																														
SEBRING	2007	ABS (Anti Lock Brake System)	V																																													
SEBRING	2007	AMP (Audio)																						V	V																							
SEBRING	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
SEBRING	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
SEBRING	2007	DDM (Drivers Door Module)																					V																									
SEBRING	2007	HFM (Hands Free Module)																																								V						
SEBRING	2007	HVAC (Heat Vent A/C)																								V	V	V	V																			
SEBRING	2007	ITM (Intrusion)																																														
SEBRING	2007	ORC (Occupant Restraint Control)		V																																												
SEBRING	2007	PDM (Passenger Door Module)																																														
SEBRING	2007	RADIO (Radio)																																				V	V	V	V							
SEBRING	2007	SAS (Steering Angle Sensor)																																														
SEBRING	2007	TCM (Transmission Control Module)																																														
SEBRING	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
SEBRING	2007	VES3 (Vidio Entertainment System 3)																																														
SEBRING	2007	WCM(Wireless Control Modules)														V																											V	V				
TOWN/COUNTRY	2016	PCM (Powertrain Control Module)																																														
TOWN/COUNTRY	2016	ABS (Anti Lock Brake System)																																														
TOWN/COUNTRY	2016	AHBM (Automatic High Beam)																																														
TOWN/COUNTRY	2016	AMP (Audio)																																														
TOWN/COUNTRY	2016	BCM (Body Control Module)																																														
TOWN/COUNTRY	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
TOWN/COUNTRY	2016	CGW (Central Gateway)																																														
TOWN/COUNTRY	2016	HFM (Hands Free Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
TOWN/COUNTRY	2016	HVAC (Heat Vent A/C)																																														
TOWN/COUNTRY	2016	IPC (Instrument Panel Cluster)																																														
TOWN/COUNTRY	2016	ITM (Intrusion)																																														
TOWN/COUNTRY	2016	LBSS (Left Blind Spot Sensor)																																														
TOWN/COUNTRY	2016	MSMD (Memory Seet Module)																																														
TOWN/COUNTRY	2016	ORC (Occupant Restraint Control)																																														
TOWN/COUNTRY	2016	PTS (Park Assist Module)																																														
TOWN/COUNTRY	2016	RADIO (Radio)																																														
TOWN/COUNTRY	2016	RBSS (Right Blind Spot Sensor)																																														
TOWN/COUNTRY	2016	RFH (Radio Frequency Hub)																																														
TOWN/COUNTRY	2016	SAS (Steering Angle Sensor)																																														
TOWN/COUNTRY	2016	SUNR (Sunroof Module)																																														
TOWN/COUNTRY	2016	TCM (Transmission Control Module)																																														
TOWN/COUNTRY	2016	TPM (Tire Pressure Monitor)																																														
TOWN/COUNTRY	2016	VES3 (Vidio Entertainment System 3)																																														
TOWN/COUNTRY	2016	WCM(Wireless Control Modules)																																														
TOWN/COUNTRY	2015	PCM (Powertrain Control Module)																																														
TOWN/COUNTRY	2015	ABS (Anti Lock Brake System)																																														
TOWN/COUNTRY	2015	AHBM (Automatic High Beam)																																														
TOWN/COUNTRY	2015	AMP (Audio)																																														
TOWN/COUNTRY	2015	BCM (Body Control Module)																																														
TOWN/COUNTRY	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
TOWN/COUNTRY	2015	CGW (Central Gateway)																																														
TOWN/COUNTRY	2015	HFM (Hands Free Module)																																														
TOWN/COUNTRY	2015	HVAC (Heat Vent A/C)																																														
TOWN/COUNTRY	2015	IPC (Instrument Panel Cluster)																																														
TOWN/COUNTRY	2015	ITM (Intrusion)																																														
TOWN/COUNTRY	2015	LBSS (Left Blind Spot Sensor)																																														
TOWN/COUNTRY	2015	MSMD (Memory Seet Module)																																														
TOWN/COUNTRY	2015	ORC (Occupant Restraint Control)																																														
TOWN/COUNTRY	2015	PTS (Park Assist Module)																																														
TOWN/COUNTRY	2015	RADIO (Radio)																																														
TOWN/COUNTRY	2015	RBSS (Right Blind Spot Sensor)																																														
TOWN/COUNTRY	2015	RFH (Radio Frequency Hub)																																														
TOWN/COUNTRY	2015	SAS (Steering Angle Sensor)																																														
TOWN/COUNTRY	2015	SUNR (Sunroof Module)																																														
TOWN/COUNTRY	2015	TCM (Transmission Control Module)																																														
TOWN/COUNTRY	2015	TPM (Tire Pressure Monitor)																																														
TOWN/COUNTRY	2015	VES3 (Vidio Entertainment System 3)																																														
TOWN/COUNTRY	2015	WCM(Wireless Control Modules)																																														
TOWN/COUNTRY	2014	PCM (Powertrain Control Module)																																														
TOWN/COUNTRY	2014	ABS (Anti Lock Brake System)	V																																													

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
TOWN/COUNTRY	2014	AHBM (Automatic High Beam)																																														
TOWN/COUNTRY	2014	AMP (Audio)																						V	V																							
TOWN/COUNTRY	2014	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
TOWN/COUNTRY	2014	HFM (Hands Free Module)																																								V						
TOWN/COUNTRY	2014	HSM (Heated Seat Module)																																														
TOWN/COUNTRY	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
TOWN/COUNTRY	2014	ITM (Intrusion)																																														
TOWN/COUNTRY	2014	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
TOWN/COUNTRY	2014	ORC (Occupant Restraint Control)		V																																												
TOWN/COUNTRY	2014	PLM (Power Liftgate Module)																																														
TOWN/COUNTRY	2014	PTS (Park Assist Module)																																														
TOWN/COUNTRY	2014	RADIO (Radio)																																				V	V	V	V							
TOWN/COUNTRY	2014	SAS (Steering Angle Sensor)																																														
TOWN/COUNTRY	2014	SUNR (Sunroof Module)																																														
TOWN/COUNTRY	2014	TCM (Transmission Control Module)																																														
TOWN/COUNTRY	2014	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
TOWN/COUNTRY	2014	TPM (Tire Pressure Monitor)																																														
TOWN/COUNTRY	2014	VES3 (Vidio Entertainment System 3)																																														
TOWN/COUNTRY	2014	WCM(Wireless Control Modules)														V																											V	V				
TOWN/COUNTRY	2013	PCM (Powertrain Control Module)																																														
TOWN/COUNTRY	2013	ABS (Anti Lock Brake System)	V																																													
TOWN/COUNTRY	2013	AHBM (Automatic High Beam)																																														
TOWN/COUNTRY	2013	AMP (Audio)																						V	V																							
TOWN/COUNTRY	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
TOWN/COUNTRY	2013	HFM (Hands Free Module)																																								V						
TOWN/COUNTRY	2013	HSM (Heated Seat Module)																																														
TOWN/COUNTRY	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
TOWN/COUNTRY	2013	ITM (Intrusion)																																														
TOWN/COUNTRY	2013	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
TOWN/COUNTRY	2013	ORC (Occupant Restraint Control)		V																																												
TOWN/COUNTRY	2013	PLM (Power Liftgate Module)																																														
TOWN/COUNTRY	2013	PTS (Park Assist Module)																																														
TOWN/COUNTRY	2013	RADIO (Radio)																																				V	V	V	V							
TOWN/COUNTRY	2013	SAS (Steering Angle Sensor)																																														
TOWN/COUNTRY	2013	SUNR (Sunroof Module)																																														
TOWN/COUNTRY	2013	TCM (Transmission Control Module)																																														
TOWN/COUNTRY	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
TOWN/COUNTRY	2013	TPM (Tire Pressure Monitor)																																														
TOWN/COUNTRY	2013	VES3 (Vidio Entertainment System 3)																																														
TOWN/COUNTRY	2013	WCM(Wireless Control Modules)														V																											V	V				
TOWN/COUNTRY	2012	PCM (Powertrain Control Module)																																														
TOWN/COUNTRY	2012	ABS (Anti Lock Brake System)	V																																													

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
TOWN/COUNTRY	2012	AHBM (Automatic High Beam)																																														
TOWN/COUNTRY	2012	AMP (Audio)																						V	V																							
TOWN/COUNTRY	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
TOWN/COUNTRY	2012	HFM (Hands Free Module)																																								V						
TOWN/COUNTRY	2012	HSM (Heated Seat Module)																																														
TOWN/COUNTRY	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
TOWN/COUNTRY	2012	ITM (Intrusion)																																														
TOWN/COUNTRY	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
TOWN/COUNTRY	2012	ORC (Occupant Restraint Control)		V																																												
TOWN/COUNTRY	2012	PLM (Power Liftgate Module)																																														
TOWN/COUNTRY	2012	PTS (Park Assist Module)																																														
TOWN/COUNTRY	2012	RADIO (Radio)																																				V	V	V	V							
TOWN/COUNTRY	2012	SAS (Steering Angle Sensor)																																														
TOWN/COUNTRY	2012	SUNR (Sunroof Module)																																														
TOWN/COUNTRY	2012	TCM (Transmission Control Module)																																														
TOWN/COUNTRY	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
TOWN/COUNTRY	2012	TPM (Tire Pressure Monitor)																																														
TOWN/COUNTRY	2012	VES3 (Vidio Entertainment System 3)																																														
TOWN/COUNTRY	2012	WCM(Wireless Control Modules)														V																											V	V				
TOWN/COUNTRY	2011	PCM (Powertrain Control Module)																																														
TOWN/COUNTRY	2011	AHBM (Automatic High Beam)																																														
TOWN/COUNTRY	2011	AMP (Audio)																						V	V																							
TOWN/COUNTRY	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
TOWN/COUNTRY	2011	HFM (Hands Free Module)																																								V						
TOWN/COUNTRY	2011	HSM (Heated Seat Module)																																														
TOWN/COUNTRY	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
TOWN/COUNTRY	2011	ITM (Intrusion)																																														
TOWN/COUNTRY	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
TOWN/COUNTRY	2011	ORC (Occupant Restraint Control)		V																																												
TOWN/COUNTRY	2011	PLM (Power Liftgate Module)																																														
TOWN/COUNTRY	2011	PTS (Park Assist Module)																																														
TOWN/COUNTRY	2011	RADIO (Radio)																																				V	V	V	V							
TOWN/COUNTRY	2011	SAS (Steering Angle Sensor)																																														
TOWN/COUNTRY	2011	SUNR (Sunroof Module)																																														
TOWN/COUNTRY	2011	TCM (Transmission Control Module)																																														
TOWN/COUNTRY	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
TOWN/COUNTRY	2011	TPM (Tire Pressure Monitor)																																														
TOWN/COUNTRY	2011	VES3 (Vidio Entertainment System 3)																																														
TOWN/COUNTRY	2011	WCM(Wireless Control Modules)														V																											V	V				
TOWN/COUNTRY	2010	PCM (Powertrain Control Module)																																														
TOWN/COUNTRY	2010	ABS (Anti Lock Brake System)	V																																													
TOWN/COUNTRY	2010	AHBM (Automatic High Beam)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
TOWN/COUNTRY	2010	AMP (Audio)																						V	V																					
TOWN/COUNTRY	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																								
TOWN/COUNTRY	2010	HFM (Hands Free Module)																																							V					
TOWN/COUNTRY	2010	HVAC (Heat Vent A/C)																								V	V	V	V																	
TOWN/COUNTRY	2010	ITM (Intrusion)																																												
TOWN/COUNTRY	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V									
TOWN/COUNTRY	2010	ORC (Occupant Restraint Control)		V																																										
TOWN/COUNTRY	2010	PLM (Power Liftgate Module)																																												
TOWN/COUNTRY	2010	PTS (Park Assist Module)																																												
TOWN/COUNTRY	2010	RADIO (Radio)																																				V	V	V	V						
TOWN/COUNTRY	2010	SAS (Steering Angle Sensor)																																												
TOWN/COUNTRY	2010	SUNR (Sunroof Module)																																												
TOWN/COUNTRY	2010	TCM (Transmission Control Module)																																												
TOWN/COUNTRY	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																															
TOWN/COUNTRY	2010	VES3 (Vidio Entertainment System 3)																																												
TOWN/COUNTRY	2010	WCM(Wireless Control Modules)														V																										V	V			
TOWN/COUNTRY	2009	PCM (Powertrain Control Module)																																												
TOWN/COUNTRY	2009	ABS (Anti Lock Brake System)	V																																											
TOWN/COUNTRY	2009	AHBM (Automatic High Beam)																																												
TOWN/COUNTRY	2009	AMP (Audio)																						V	V																					
TOWN/COUNTRY	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																								
TOWN/COUNTRY	2009	HFM (Hands Free Module)																																							V					
TOWN/COUNTRY	2009	HVAC (Heat Vent A/C)																								V	V	V	V																	
TOWN/COUNTRY	2009	ITM (Intrusion)																																												
TOWN/COUNTRY	2009	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V									
TOWN/COUNTRY	2009	ORC (Occupant Restraint Control)		V																																										
TOWN/COUNTRY	2009	PLM (Power Liftgate Module)																																												
TOWN/COUNTRY	2009	PTS (Park Assist Module)																																												
TOWN/COUNTRY	2009	RADIO (Radio)																																				V	V	V	V						
TOWN/COUNTRY	2009	SAS (Steering Angle Sensor)																																												
TOWN/COUNTRY	2009	SUNR (Sunroof Module)																																												
TOWN/COUNTRY	2009	TCM (Transmission Control Module)																																												
TOWN/COUNTRY	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																															
TOWN/COUNTRY	2009	VES3 (Vidio Entertainment System 3)																																												
TOWN/COUNTRY	2009	WCM(Wireless Control Modules)														V																										V	V			
TOWN/COUNTRY	2008	PCM (Powertrain Control Module)																																												
TOWN/COUNTRY	2008	ABS (Anti Lock Brake System)	V																																											
TOWN/COUNTRY	2008	AHBM (Automatic High Beam)																																												
TOWN/COUNTRY	2008	AMP (Audio)																						V	V																					
TOWN/COUNTRY	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																								
TOWN/COUNTRY	2008	HFM (Hands Free Module)																																							V					
TOWN/COUNTRY	2008	HVAC (Heat Vent A/C)																								V	V	V	V																	

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
TOWN/COUNTRY	2008	ITM (Intrusion)																																														
TOWN/COUNTRY	2008	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
TOWN/COUNTRY	2008	ORC (Occupant Restraint Control)		V																																												
TOWN/COUNTRY	2008	PLM (Power Liftgate Module)																																														
TOWN/COUNTRY	2008	PTS (Park Assist Module)																																														
TOWN/COUNTRY	2008	RADIO (Radio)																																				V	V	V	V							
TOWN/COUNTRY	2008	SAS (Steering Angle Sensor)																																														
TOWN/COUNTRY	2008	SUNR (Sunroof Module)																																														
TOWN/COUNTRY	2008	TCM (Transmission Control Module)																																														
TOWN/COUNTRY	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
TOWN/COUNTRY	2008	VES3 (Vidio Entertainment System 3)																																														
TOWN/COUNTRY	2008	WCM(Wireless Control Modules)														V																												V	V				

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	Electric throttle learning	VIN	Air Bleeding(Japan Domestic)	Air Bleeding(International)	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialization	Back Up Memory Clear	Test Mode	Inspection Mode	ECB Utility	VSC Sensor Neutral Memorization	Transponder Code Erasure	Transponder Code Registration	Re-centring of autoadaptive systems	Initialising the autoadaptives	Gearbox actuator initialisation	Locking	Unlocking	Configuration	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve
C1	Engine ECU	Petrol engine	ME795	V	V	V		V																														
C1	Gearbox ECU	MMT		V	V	V			V	V																												
C1	Airbag	Airbag		V	V																																	
C1	ABS or ESP	ABS or ESP		V	V	V					V																											
C1	Coded anti-start	ADC		V	V	V						V	V																									
C1	Power steering	DAE		V	V									V	V																							
C1(B4)	Engine ECU	ME17_9_52		V	V	V	V									V	V																					
C1(B4)	ABS	RBV		V	V	V												V	V	V	V	V	V	V	V	V	V											
C1(B4)	EPS	EPS_T		V	V									V																								
C1(B4)	Instrument panel	MET		V	V	V																																
C1(B4)	Immobilizer	Immobilizer		V	V																							V	V									
C2	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LPC	V	V	V	V																							V								
C2	Injection	Petrol (6th to 8th digit of VIN)	TU1A J34P	V	V	V	V																															
C2	Injection	Petrol (6th to 8th digit of VIN)	TU3A J34P	V	V	V	V																															
C2	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745	V	V	V	V																								V							
C2	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745	V	V	V	V																								V							
C2	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745	V	V	V	V																								V							
C2	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745	V	V	V	V																								V							
C2	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM2	V	V	V	V																							V								
C2	Injection	Diesel (6th to 8th digit of VIN)	9HZ(FAP) BOSCH EDC16C34 DV6TED4	V	V	V	V																															
C2	Injection	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C34 DV4TD	V	V	V	V																															
C2	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID806	V	V	V	V																															
C2	Gearbox ECU	Gearbox ECU		V	V	V	V																									V						
C2	Airbag	Airbag		V	V		V																										V	V	V			
C2	Anti-lock brake system	ABS MK 70		V	V	V	V																												V	V	V	V
C2	Anti-lock brake system	ABS MK70.1		V	V	V	V																															
C2	Anti-lock brake system	ESP MK60		V	V	V	V																															
C2	Anti-lock brake system	ESP MK60-O		V	V	V	V																															
C2	BSI	BSI		V																																		
C2	Instrument panel	Instrument panel		V	V	V	V																												V			
C2	Radio	Radio		V	V	V	V																															
C2	CD player	CD player		V		V	V																															
C2	Parking aid	Parking aid		V	V	V	V																												V			
C2	Air conditioning	Air conditioning		V	V	V	V																												V			
C2	Switch module under the steering wheel	Switch module under the steering wheel		V	V	V	V																															
C2	Rain sensor Brightness	Rain sensor / Brightness		V			V																															

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	Electric throttle learning	VIN	Air Bleeding(Japan Domestic)	Air Bleeding(International)	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialization	Back Up Memory Clear	Test Mode	Inspection Mode	ECB Utility	VSC Sensor Neutral Memorization	Transponder Code Erasure	Transponder Code Registration	Re-centring of autoadaptive systems	Initialising the autoadaptives	Gearbox actuator initialisation	Locking	Unlocking	Configuration	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve
C2	Multifunction screen	Multifunction screen		V	V	V	V																															
C2	Electric power steering ECU	Electric power steering ECU		V	V		V																															
C3	Injection	Petrol (6th to 8th digit of VIN)	HFX MM48P	V	V	V	V																								V							
C3	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP	V	V	V	V																															
C3	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME744	V	V	V	V																								V			V				
C3	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME744	V	V	V	V																								V			V				
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV BOSCH ME744	V	V	V	V																								V			V				
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM1	V	V	V	V																								V			V				
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM2	V	V	V	V																								V			V				
C3	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749	V	V	V	V																								V							
C3	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749	V	V	V	V																								V							
C3	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME749	V	V	V	V																								V							
C3	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME749	V	V	V	V																								V							
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV BOSCH ME749	V	V	V	V																								V							
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 5FS	V	V	V	V																															
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 8FR	V	V	V	V																															
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 8FP	V	V	V	V																															
C3	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 CV6ATED4	V	V	V	V																															
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C34 DV4TD	V	V	V	V																															
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX BOSCH EDC16C34 DV4TD	V	V	V	V																															
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX SIEMENS SID802	V	V	V	V																															
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX SIEMENS SID804	V	V	V	V																															
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID804	V	V	V	V																															
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID806	V	V	V	V																															
C3	Injection	Diesel (6th to 8th digit of VIN)	8HY DELPHI C6	V	V	V	V																															
C3	Gearbox ECU	Auto gearbox BVA_AL4		V	V	V	V																															
C3	Gearbox ECU	Controlled manual gearbox ECU		V	V	V	V																															
C3	Airbag	Airbag		V	V		V																															
C3	Anti-lock brake system	ABS MK60		V	V	V	V																											V	V	V	V
C3	Anti-lock brake system	ABS MK70		V	V	V	V																											V	V	V	V
C3	Anti-lock brake system	ESP		V	V	V	V																															
C3	BSI	BSI		V	V	V	V																															
C3	Instrument panel	Instrument panel		V	V	V	V																															
C3	Radio	Radio		V	V	V	V																															
C3	CD player	CD player		V	V	V	V																															
C3	Parking aid	Parking aid		V	V	V	V																															

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	Electric throttle learning	VIN	Air Bleeding(Japan Domestic)	Air Bleeding(International)	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialization	Back Up Memory Clear	Test Mode	Inspection Mode	ECB Utility	VSC Sensor Neutral Memorization	Transponder Code Erasure	Transponder Code Registration	Re-centring of autoadaptive systems	Initialising the autoadaptives	Gearbox actuator initialisation	Locking	Unlocking	Configuration	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve
C3	Air conditioning	Air conditioning		V	V	V	V																															
C3	Navigation	Navigation		V	V		V																															
C3	Alarm	Alarm		V		V	V																															
C3	Switch module under the steering wheel	Switch module under the steering wheel		V	V		V																															
C3	Diesel additive function	Diesel additive function		V	V	V	V																															
C3	Rain sensor Brightness	Rain sensor / Brightness		V			V																															
C3	Driving school mode	Driving school mode			V	V	V																															
C3	Multifunction display	Multifunction display		V																																		
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FT MED17.4	V	V	V	V																															
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FX MED17.4	V	V	V	V																															
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4	V	V	V	V																															
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFN MM6LP	V	V	V	V																							V								
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFK MM6LP	V	V	V	V																							V								
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP	V	V	V	V																							V								
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB	V	V	V	V																							V								
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	6FY MM6LPB	V	V	V	V																							V								
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745	V	V	V	V																								V				V			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745	V	V	V	V																								V							
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745	V	V	V	V																								V							
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745	V	V	V	V																								V							
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749	V	V	V	V																								V							
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749	V	V	V	V																								V							
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	MM6KP Bio Flex	V	V	V	V																							V								
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 23A	V	V	V	V																															
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 HMU	V	V	V	V																															
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 HMZ	V	V	V	V																															
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR DELPHI DCM3.4	V	V	V	V																															
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHF DELPHI DCM3.4	V	V	V	V																															
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C34 DV6TED4	V	V	V	V																															
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4	V	V	V	V																															
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4	V	V	V	V																															
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C34 DV6TED4	V	V	V	V																															
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A	V	V	V	V																															
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803	V	V	V	V																															
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	Engine type 42 : EB2DTS engine with 5-speed manual gearbox	V	V	V	V																															
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	Engine type 44 : EB2DTS engine with 6-speed manual gearbox	V	V	V	V																															

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	Electric throttle learning	VIN	Air Bleeding(Japan Domestic)	Air Bleeding(International)	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialization	Back Up Memory Clear	Test Mode	Inspection Mode	ECB Utility	VSC Sensor Neutral Memorization	Transponder Code Erasure	Transponder Code Registration	Re-centring of autoadaptive systems	Initialising the autoadaptives	Gearbox actuator initialisation	Locking	Unlocking	Configuration	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve
C3 PLURIEL	Gearbox ECU	BVA_AL4_AT8		V	V	V	V																															
C3 PLURIEL	Gearbox ECU	Controlled manual gearbox (BVMP)		V	V	V	V																									V						
C3 PLURIEL	BSI	BSI		V																																		
C3 PLURIEL	Airbag	Airbag		V	V		V																										V	V	V			
C3 PLURIEL	ABS or ESP	ABS_MK70.1		V	V	V	V																															
C3 PLURIEL	ABS or ESP	ESP MK60-O		V	V	V	V																															
C3 PLURIEL	Instrument panel	Instrument panel		V	V	V	V																												V			
C3 PLURIEL	Radio	Radio		V	V	V	V																															
C3 PLURIEL	Multifunction display	Multifunction display		V	V	V	V																															
C3 PLURIEL	Power steering electric pump unit	Power steering electric pump unit		V	V		V																															
C3 PLURIEL	Switch module at the steering wheel	Switch module at the steering wheel		V	V	V	V																															
C3 PLURIEL	Sun roof	Sun roof		V	V	V	V																												V			
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4	V	V	V	V																															
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FS MEV17.4	V	V	V	V																															
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FP MEV17.4	V	V	V	V																															
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FS MEV17.4.2	V	V	V	V																															
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FP MEV17.4.2	V	V	V	V																															
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FR MED17.4	V	V	V	V																															
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV	V	V	V	V																															
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4- 90CV	V	V	V	V																															
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HR HDI SID807	V	V	V	V																															
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	EDC17C10 BR2	V	V	V	V																															
C3 PICASSO	Gearbox ECU	BVA_AT8		V	V	V	V																															
C3 PICASSO	Gearbox ECU	CFC300P		V	V	V	V																															
C3 PICASSO	Gearbox ECU	BVA AM6 Euro5		V	V	V	V																															
C3 PICASSO	BSI	BSI		V																																		
C3 PICASSO	Airbag	Airbag		V	V		V																															
C3 PICASSO	ABS	ESP_MK60		V	V	V	V																															
C3 PICASSO	ABS	ABS MK 70.2		V	V	V	V																															
C3 PICASSO	Instrument panel	Instrument panel		V	V	V	V																												V			
C3 PICASSO	Parking aid	Parking aid		V	V		V																															
C3 PICASSO	Air conditioning	Air conditioning		V	V	V	V																												V			
C3 PICASSO	Switch module under the steering wheel	Switch module under the steering wheel		V	V	V	V																															
C3 PICASSO	Multifunction display	Multifunction display		V	V	V	V																															
C3 PICASSO	Multiplexed additive pump	POMPE_MUX_MGI		V	V	V	V																															
C3 PICASSO	Electric power steering	DAE		V	V	V	V																															

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	Electric throttle learning	VIN	Air Bleeding(Japan Domestic)	Air Bleeding(International)	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialization	Back Up Memory Clear	Test Mode	Inspection Mode	ECB Utility	VSC Sensor Neutral Memorization	Transponder Code Erasure	Transponder Code Registration	Re-centring of autoadaptive systems	Initialising the autoadaptives	Gearbox actuator initialisation	Locking	Unlocking	Configuration	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve
C3 PICASSO	Battery charge status unit	Battery charge status unit		V	V		V																												V			
C3 PICASSO	Engine relay unit	Engine relay unit		V																																		
C3 PICASSO	Trailer relay unit	Trailer relay unit		V																																		
C3 PICASSO	Radio	Radio		V	V	V	V																															
C3 PICASSO	Driver's door module	Driver's door module		V	V	V	V																															
C3 PICASSO	Rain sensor	Rain sensor		V			V																															
C3 PICASSO	Central voltage retention device	Central voltage retention device					V																															
C4	Injection	Petrol (6th to 8th digit of VIN)	5FT MED17.4	V	V	V	V																															
C4	Injection	Petrol (6th to 8th digit of VIN)	5FX MED17.4	V	V	V	V																															
C4	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4	V	V	V	V																															
C4	Injection	Petrol (6th to 8th digit of VIN)	RFN MM6LP	V	V	V	V																							V								
C4	Injection	Petrol (6th to 8th digit of VIN)	RFK MM6LP	V	V	V	V																							V								
C4	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP	V	V	V	V																							V								
C4	Injection	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB	V	V	V	V																							V								
C4	Injection	Petrol (6th to 8th digit of VIN)	6FY MM6LPB	V	V	V	V																							V								
C4	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745	V	V	V	V																								V				V			
C4	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745	V	V	V	V																								V							
C4	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745	V	V	V	V																								V							
C4	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745	V	V	V	V																								V							
C4	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749	V	V	V	V																								V							
C4	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749	V	V	V	V																								V							
C4	Injection	Petrol (6th to 8th digit of VIN)	MM6KP Bio Flex	V	V	V	V																							V								
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 23A	V	V	V	V																															
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 HMU	V	V	V	V																															
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 HMZ	V	V	V	V																															
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR DELPHI DCM3.4	V	V	V	V																															
C4	Injection	Diesel (6th to 8th digit of VIN)	RHF DELPHI DCM3.4	V	V	V	V																															
C4	Injection	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C34 DV6TED4	V	V	V	V																															
C4	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4	V	V	V	V																															
C4	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4	V	V	V	V																															
C4	Injection	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C34 DV6TED4	V	V	V	V																															
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A	V	V	V	V																															
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803	V	V	V	V																															
C4	Injection	Diesel (6th to 8th digit of VIN)	Engine type 42 : EB2DTS engine with 5-speed manual gearbox	V	V	V	V																															
C4	Injection	Diesel (6th to 8th digit of VIN)	Engine type 44 : EB2DTS engine with 6-speed manual gearbox	V	V	V	V																															
C4	Gearbox ECU	Auto gearbox AL4		V	V	V	V																															

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	Electric throttle learning	VIN	Air Bleeding(Japan Domestic)	Air Bleeding(International)	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialization	Back Up Memory Clear	Test Mode	Inspection Mode	ECB Utility	VSC Sensor Neutral Memorization	Transponder Code Erasure	Transponder Code Registration	Re-centring of autoadaptive systems	Initialising the autoadaptives	Gearbox actuator initialisation	Locking	Unlocking	Configuration	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve
C4	Gearbox ECU	Auto gearbox AL4		V	V	V	V																															
C4	Gearbox ECU	Auto gearbox AM6		V	V	V	V																															
C4	Gearbox ECU	CFC300P		V	V	V	V																															
C4	Gearbox ECU	BVA AM6 Euro5		V	V	V	V																															
C4	BSI	BSI		V																																		
C4	Airbag	Airbag		V	V		V																										V	V	V			
C4	ABS or ESP	ABS 8_Bosch		V	V	V	V																															
C4	ABS or ESP	ESP 8_1		V	V	V	V																															
C4	ECU at the top of the steering column	ECU at the top of the steering column		V	V	V	V																															
C4	Instrument panel	Instrument panel		V	V	V	V																												V			
C4	Radio	Radio		V	V	V	V																															
C4	CD player	CD player		V	V	V	V																															
C4	Parking aid	Parking aid		V	V	V	V																												V			
C4	Air conditioning	Air conditioning		V	V	V	V																												V			
C4	Multifunction display	Multifunction display		V	V	V	V																															
C4	Power steering electric pump unit	Power steering electric pump unit		V	V		V																															
C4	Engine relay unit	Engine relay unit		V																																		
C4	Trailer relay unit	Trailer relay unit		V																																		
C4	Remote instrument panel unit	Remote instrument panel unit		V	V	V	V																															
C4	Passenger door electronics	Passenger door electronics		V	V	V	V																															
C4	Driver's door electronics	Driver's door electronics		V	V	V	V																															
C4 II	Engine(6th to 8th digit of VIN)	MED17_4_2	5FV MED17_4_2 EURO5	V	V	V	V																															
C4 II	Engine(6th to 8th digit of VIN)	EDC17C10 BR2		V	V	V	V																															
C4 II	Engine(6th to 8th digit of VIN)	9HR HDI SID807		V	V	V	V																															
C4 II	Gearbox ECU	BVA_AT8		V	V	V	V																															
C4 II	Gearbox ECU	CFC300P		V	V	V	V																															
C4 II	Gearbox ECU	BVA AM6 Euro5		V	V	V	V																															
C4 II	Airbag	RBG_UDS		V	V		V																										V	V				
C4 II	ABS Electronic stability program	ESP 8.1		V	V	V	V																															
C4 II	BSI	BSI		V			V																															
C4 II	Power steering electric pump unit	GET		V	V	V	V																															
C4 II	Battery charge status unit	Battery charge status unit		V	V		V																												V			
C4 II	Engine relay unit	Engine relay unit		V	V	V	V																															
C4 II	Display	Display		V		V	V																															
C4 II	Driver's door module	Driver's door module		V	V	V	V																															
C4 II	Electric secondary brake	Electric secondary brake		V	V	V	V																															

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	Electric throttle learning	VIN	Air Bleeding(Japan Domestic)	Air Bleeding(International)	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialization	Back Up Memory Clear	Test Mode	Inspection Mode	ECB Utility	VSC Sensor Neutral Memorization	Transponder Code Erasure	Transponder Code Registration	Re-centring of autoadaptive systems	Initialising the autoadaptives	Gearbox actuator initialisation	Locking	Unlocking	Configuration	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve
C4 II	Trailer relay unit	Trailer relay unit		V																																		
C4 II	Seat belts not fastened LED unit	Seat belts not fastened LED unit				V	V																															
C4 II	Multiplexed control panel	Multiplexed control panel		V	V	V	V																															
C4 II	Controls on the steering wheel	Controls on the steering wheel		V	V	V	V																															
C4 II	Supply protection and management unit	Supply protection and management unit			V		V																															
C4 II	Windscreen wiper	Windscreen wiper		V	V	V	V																															
C4 II	Switch module at the steering wheel	Switch module at the steering wheel		V	V	V	V																															
C4 II	Heatingventilation	Heating/ventilation		V	V	V	V																												V			
C4 II	Instrument panel	Instrument panel		V	V	V	V																															
C4 II	Radio or radiotelephone	Radio or radiotelephone		V	V	V	V																															
C4 II	Passenger door electronics	Passenger door electronics		V	V	V	V																															
C4 II	Rain and brightness sensor	Rain and brightness sensor		V			V																															
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FT MED17.4	V	V	V	V																															
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FX MED17.4	V	V	V	V																															
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FW MEV17.4	V	V	V	V																															
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB	V	V	V	V																							V								
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	6FY MM6LPB	V	V	V	V																							V								
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FV MED17_4_2	V	V	V	V																															
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HZ(FAP) BOSCH EDC16C34 DV6TED4	V	V	V	V																															
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A	V	V	V	V																															
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	RHJ SIEMENS SID803A	V	V	V	V																															
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HR HDI SID807	V	V	V	V																															
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HL - DV6CTED - 111 CV HDI_SID807_BR2	V	V	V	V																															
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HR - DV6CTED - 111 CV HDI_SID807_BR2	V	V	V	V																															
C4 PICASSO	Gearbox ECU	Auto gearbox AL4		V	V	V	V																															
C4 PICASSO	Gearbox ECU	Auto gearbox AL4		V	V	V	V																															
C4 PICASSO	Gearbox ECU	Auto gearbox AM6		V	V	V	V																															
C4 PICASSO	Gearbox ECU	CFC300P		V	V	V	V																															
C4 PICASSO	Gearbox ECU	BVA AM6 Euro5		V	V	V	V																															
C4 PICASSO	Driver and passenger airbags	Driver and passenger airbags		V	V		V																										V	V	V			
C4 PICASSO	ABS Electronic stability program	ESP 8.1		V	V	V	V																															
C4 PICASSO	ABS Electronic stability program	90 ESP		V	V	V	V																															
C4 PICASSO	BSI	BSI		V			V																															
C4 PICASSO	Power steering electric pump unit(GEP)	Power steering electric pump unit(GEP)		V	V	V	V																															
C4 PICASSO	Power steering electric pump unit(GEP)	Power steering electric pump unit(GEP)		V	V	V	V																															
C4 PICASSO	Battery charge status unit	Battery charge status unit		V	V		V																												V			

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	Electric throttle learning	VIN	Air Bleeding(Japan Domestic)	Air Bleeding(International)	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialization	Back Up Memory Clear	Test Mode	Inspection Mode	ECB Utility	VSC Sensor Neutral Memorization	Transponder Code Erasure	Transponder Code Registration	Re-centring of autoadaptive systems	Initialising the autoadaptives	Gearbox actuator initialisation	Locking	Unlocking	Configuration	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve
C4 PICASSO	Electric secondary brake	Electric secondary brake		V	V	V	V																															
C4 PICASSO	Engine relay unit	Engine relay unit		V																																		
C4 PICASSO	Trailer relay unit	Trailer relay unit		V																																		
C4 PICASSO	Windscreen wiper	Windscreen wiper		V	V	V	V																															
C4 PICASSO	ECU at the top of the steering column	ECU at the top of the steering column		V	V	V	V																															
C4 PICASSO	Heatingventilation	Heating/ventilation		V			V																															
C4 PICASSO	Instrument panel	Instrument panel		V	V	V	V																												V			
C4 PICASSO	Radio or radiotelephone	Radio or radiotelephone		V	V	V	V																															
C4 PICASSO	Passenger door electronics	Passenger door electronics		V	V	V	V																															
C4 PICASSO	Passenger door electronics	Passenger door electronics		V	V	V	V																															
C4 PICASSO	Driver's door electronics	Driver's door electronics		V	V	V	V																															
C4 PICASSO	Driver's door electronics	Driver's door electronics		V	V	V	V																															
C4 PICASSO	Rain and brightness sensor	Rain and brightness sensor		V			V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	EDC17C10_BR2		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	EDC17C10_BR2		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	DCM3.5_BR2		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	SID807		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	5FW MEV 17.4		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	8FS MEV 17.4		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	MED17_4_4		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	9HX EDC16C3		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	9HY EDC16C3		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	9HZ EDC16C3		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	9HV EDC16C3		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	RHR DCM 3.4		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	RHL DCM 3.4		V	V	V	V																															
C4 Cactus	Engine(6th to 8th digit of VIN)	RHF DCM 3.4		V	V	V	V																															
C4 Cactus	Gearbox ECU	AM6 Euro5 automatic gearbox		V	V	V	V																															
C4 Cactus	Gearbox ECU	AT6 Euro5 automatic gearbox		V	V	V	V																															
C4 Cactus	Gearbox ECU	CFC300P gearbox		V	V	V	V																															
C4 Cactus	Gearbox ECU	AL4 automatic gearbox		V	V	V	V																															
C4 Cactus	Gearbox ECU	BVA_AM6_AT6_UDS		V		V	V																															
C4 Cactus	Multiplexed additive adding pump ECU	Multiplexed additive adding pump ECU		V	V	V	V																															
C4 Cactus	ABS or ESP ECU	ESP 81		V	V	V	V																															
C4 Cactus	ABS or ESP ECU	ESP MK 100		V	V	V	V																															

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	Electric throttle learning	VIN	Air Bleeding(Japan Domestic)	Air Bleeding(International)	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialization	Back Up Memory Clear	Test Mode	Inspection Mode	ECB Utility	VSC Sensor Neutral Memorization	Transponder Code Erasure	Transponder Code Registration	Re-centring of autoadaptive systems	Initialising the autoadaptives	Gearbox actuator initialisation	Locking	Unlocking	Configuration	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve
C4 Cactus	ABS or ESP ECU	90 ESP		V	V	V	V																															
C4 Cactus	Headlamp height adjuster directional headlamp	Headlamp height adjuster/ directional headlamp		V	V	V	V																															
C4 Cactus	Built-In system interface	Built-In system interface		V			V																															
C4 Cactus	Built-In system interface	Built-In system interface		V																																		
C4 Cactus	Power steering electric pump unit	GEP		V		V	V																															
C4 Cactus	Power steering electric pump unit	DAE_BVH2		V	V		V																															
C4 Cactus	Battery charge status unit	BECB_GEN2		V	V		V																												V			
C4 Cactus	Electric secondary brake	FSE		V	V	V	V																															
C4 Cactus	Engine relay unit	BSM		V	V	V	V																															
C4 Cactus	Trailer relay unit	BSR		V																																		
C4 Cactus	Airbag ECU	RBG_UDS		V	V		V																										V	V				
C4 Cactus	Airbag ECU	RBG_UDS		V	V		V																															
C4 Cactus	Airbag ECU	SAC_AUTOLIV		V	V		V																										V	V	V			
C4 Cactus	Instrument panel	COMBINE		V	V	V	V																															
C4 Cactus	Instrument panel	COMBINE		V	V	V	V																												V			
C4 Cactus	Rain-sunlight sensor	Rain and brightness sensor		V			V																															
C4 Cactus	Rain-sunlight sensor	CDPL_UDS_HELLA		V	V		V																															
C4 Cactus	Switch module at the steering wheel	COM2008P		V	V	V	V																															
C4 Cactus	Switch module at the steering wheel	HDC		V	V	V	V																															
C4 Cactus	Bodywork conversion unit	BTC		V	V		V																															
C4 Cactus	Parking aid	AAS		V	V		V																															
C4 Cactus	Additional heating	CHAUFF_ADD		V	V	V	V																															
C4 Cactus	Telematics unit	SMEG_PLUS		V	V	V	V																															
C4 Cactus	Anti-theft alarm	ALARME		V		V	V																															
C4 Cactus	Rear air conditioning table	TAB_CLIM_AR		V	V	V	V																															
C4 Cactus	Rain and brightness sensor	PLUIE_LUMINOSITE		V			V																															
C4 Cactus	Supply protection and management unit	BPGA2010			V		V																															
C4 Cactus	Door control pad	PDPC_UDS		V	V	V	V																															
C4 Cactus	Air conditioning	BCC		V	V	V	V																															
C4 Cactus	Touch screen	Touch screen		V	V	V	V																															
C4 Cactus	Seat belts not fastened LED unit	TNB_2010				V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	MED17_4_2	5FV MED17_4_2 EURO5	V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	EDC17C10_BR2		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	EDC17C10_BR2		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	DCM3.5_BR2		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	SID807		V	V	V	V																															

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	Electric throttle learning	VIN	Air Bleeding(Japan Domestic)	Air Bleeding(International)	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialization	Back Up Memory Clear	Test Mode	Inspection Mode	ECB Utility	VSC Sensor Neutral Memorization	Transponder Code Erasure	Transponder Code Registration	Re-centring of autoadaptive systems	Initialising the autoadaptives	Gearbox actuator initialisation	Locking	Unlocking	Configuration	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve
C-ELYSEE	Engine(6th to 8th digit of VIN)	5FW MEV 17.4		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	8FS MEV 17.4		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	MED17_4_4		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HX EDC16C3		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HY EDC16C3		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HZ EDC16C3		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HV EDC16C3		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHR DCM 3.4		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHL DCM 3.4		V	V	V	V																															
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHF DCM 3.4		V	V	V	V																															
C-ELYSEE	Gearbox ECU	BVA_AT8		V	V	V	V																															
C-ELYSEE	Gearbox ECU	CFC300P		V	V	V	V																															
C-ELYSEE	Gearbox ECU	BVA AM6 Euro5		V	V	V	V																															
C-ELYSEE	Airbag	RBG_UDS		V	V		V																										V	V				
C-ELYSEE	ABS_Electronic stability program	ESP 8.1		V	V	V	V																															
C-ELYSEE	ABS_Electronic stability program	ABS 81		V	V	V	V																															
C-ELYSEE	BSI	BSI2010		V			V																															
C-ELYSEE	Power steering electric pump unit	GET		V	V	V	V																															
C-ELYSEE	Battery charge status unit	Battery charge status unit		V	V		V																												V			
C-ELYSEE	Electric secondary brake	Electric secondary brake		V	V	V	V																															
C-ELYSEE	Trailer relay unit	Trailer relay unit		V																																		
C-ELYSEE	Windscreen wiper	Windscreen wiper		V	V	V	V																															
C-ELYSEE	Switch module at the steering wheel	Switch module at the steering wheel		V	V	V	V																															
C-ELYSEE	Heatingventilation	Heating/ventilation		V	V	V	V																												V			
C-ELYSEE	Instrument panel	Instrument panel		V	V	V	V																															
C-ELYSEE	Radio or radiotelephone	Radio or radiotelephone		V	V	V	V																															
C-ELYSEE	Passenger door electronics	Passenger door electronics		V	V	V	V																															
C-ELYSEE	Rain and brightness sensor	Rain and brightness sensor		V			V																															
JUMPY	Injection(6th to 8th digit of VIN)	EDC16C3	9HU-DV6UTED4 - 90 CV	V	V	V	V																															
JUMPY	Injection(6th to 8th digit of VIN)	DCM3.5_BR2	AHZ-DW10CD-128CV	V	V	V	V																															
JUMPY	Anti-lock brake system	ABS 8.1		V	V	V	V																															
JUMPY	Airbag	Airbag		V	V		V																															
JUMPY	Trailer relay unit	Trailer relay unit		V																																		
JUMPY	Engine relay unit	Engine relay unit		V																																		
JUMPY	BSI	BSI		V																																		

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	Electric throttle learning	VIN	Air Bleeding(Japan Domestic)	Air Bleeding(International)	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialization	Back Up Memory Clear	Test Mode	Inspection Mode	ECB Utility	VSC Sensor Neutral Memorization	Transponder Code Erasure	Transponder Code Registration	Re-centring of autoadaptive systems	Initialising the autoadaptives	Gearbox actuator initialisation	Locking	Unlocking	Configuration	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve
JUMPY	Switch module under the steering wheel	Switch module under the steering wheel		V	V	V	V																															
JUMPY	Bodywork conversion unit	Bodywork conversion unit		V																																		
Jumper	Engine(6th to 8th digit of VIN) Gearbox	PUMA	PUMA 4HV	V	V	V	V																															
Jumper	Engine(6th to 8th digit of VIN) Gearbox	PUMA	PUMA 4HU(120 or 130)	V	V	V	V																															
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC16C39	EDC16C39 TUB	V	V	V	V																															
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52	EDC17CP52 SOFIM EURO5	V	V	V	V																															
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52_UDS 3.0 HDI 180CV E5	EDC17CP52_UDS 3.0 HDI 180CV E5	V	V	V	V																															
Jumper	Engine(6th to 8th digit of VIN) Gearbox	SID208	SID208	V	V	V	V																															
Jumper	ABSESP	ESP90_F		V	V	V	V																															
Jumper	Power steering	SSCU		V	V		V																															
Jumper	Airbag	Airbag		V	V	V	V																															
Jumper	Built-In system interface	Built-In system interface		V	V	V	V																															
Jumper	Built-In system interface	Built-In system interface		V	V		V																															
Berlingo	Driving assistance Comfort	Parking aid		V	V	V	V																															
Berlingo	Built-In system interface	Built-In system interface		V	V	V	V																															
Berlingo	Driver information Communication	Display / Telematics		V																																		
Berlingo	Driver information Communication	Radio		V	V	V	V																															
Berlingo	Driver information Communication	CD Player		V	V	V	V																															
Berlingo	Driver information Communication	Instrument panel		V	V	V	V																															
Berlingo	Driver information Communication	Switching module below steering wheel (COM 2000)		V	V		V																															
Berlingo	Airbags	Airbags		V	V		V																										V	V	V			
Berlingo	VisibilityLighting	Switching module below steering wheel (COM 2000)		V	V		V																															
Berlingo	VisibilityLighting	Rain/sunlight sensor		V			V																															
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P	V	V	V	V																								V							
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2	V	V	V	V																								V				V			
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2	V	V	V	V																								V				V			
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4	V	V	V	V																								V				V			
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P	V	V	V	V																								V							
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801	V	V	V	V																															
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2	V	V	V	V																															
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2	V	V	V	V																															
Berlingo	Active Safety	ESP BOSCH 5.7		V	V	V	V																															
Berlingo	Active Safety	ABS BOSCH 8		V	V	V	V																															
Berlingo	Active Safety	ESP BOSCH 8		V	V	V	V																															
Berlingo	Active Safety	ABS 8.1		V	V	V	V																															
Berlingo	Active Safety	ESP 8.1		V	V	V	V																															

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	Electric throttle learning	VIN	Air Bleeding(Japan Domestic)	Air Bleeding(International)	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialization	Back Up Memory Clear	Test Mode	Inspection Mode	ECB Utility	VSC Sensor Neutral Memorization	Transponder Code Erasure	Transponder Code Registration	Re-centring of autoadaptive systems	Initialising the autoadaptives	Gearbox actuator initialisation	Locking	Unlocking	Configuration	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HW DV6BTED4 - 75 CV	V	V	V	V																															
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HX DV6AUTED4 - 90 CV	V	V	V	V																															
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HX-DV6ATED4 - 90 CV	V	V	V	V																															
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HZ-DV6TED4 FAP - 110 CV	V	V	V	V																															
Berlingo II	Injection(6th to 8th digit of VIN)	EDC17C10 BR2	9HN-DV6ETED	V	V	V	V																															
Berlingo II	Anti-lock brake system	ABS 8		V	V	V	V																															
Berlingo II	Anti-lock brake system	ESP8.1_BOSCH		V	V	V	V																															
Berlingo II	Anti-lock brake system	ABS 81		V	V	V	V																															
Berlingo II	Airbag	Airbag		V	V		V																										V	V	V			
Berlingo II	Power steering electric pump unit	Power steering electric pump unit		V	V		V																															
Berlingo II	Instrument panel	Instrument panel		V	V	V	V																															
Berlingo II	Radio	RD4		V	V	V	V																															
Berlingo II	Radio	RD45		V	V	V	V																															
Berlingo II	Rain sensor Brightness	Rain sensor / Brightness		V			V																															
Berlingo II	Trailer relay unit	Trailer relay unit		V																																		
Berlingo II	Engine relay unit	Engine relay unit		V																																		
Berlingo II	Multiplexed additive pump	Multiplexed additive pump		V	V	V	V																															
Berlingo II	Multifunction display	Multifunction display		V	V	V	V																															
Berlingo II	BSI	BSI		V	V	V	V																															
Berlingo II	Switch module under the steering wheel	Switch module under the steering wheel		V	V		V																															
Berlingo II	Switch module under the steering wheel	Switch module under the steering wheel		V	V	V	V																															
NEMO	Engine(6th to 8th digit of VIN) Gearbox	EDC16C34		V	V	V	V																															
NEMO	Engine(6th to 8th digit of VIN) Gearbox	HDI_8DF3		V	V	V	V																															
NEMO	Engine(6th to 8th digit of VIN) Gearbox	BMF PUMA	BMF HDI 4C	V	V	V	V																															
NEMO	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52_UDS 3.0 HDI 180CV E5		V	V	V	V																															
NEMO	Engine(6th to 8th digit of VIN) Gearbox	SID208		V	V	V	V																															
NEMO	ABSESP	ESP 90_F		V	V	V	V																															
NEMO	ABSESP	ESP 81		V	V	V	V																															
NEMO	ABSESP	ABS 81		V	V	V	V																															
NEMO	Built-In system interface	Built-In system interface		V			V																															
NEMO	Built-In system interface	Built-In system interface		V																																		
NEMO	Built-In system interface	Built-In system interface		V	V		V																															
NEMO	Airbag	Airbag		V			V																															
NEMO	LDWS	LDWS		V	V		V																															
NEMO	Instrument	Instrument		V			V																															
NEMO	Parking control	Parking control		V			V																															

Vehicle	System 1	System 2	System 3	Rear Right Wheel Solenoid Valve	Bleeding	Service zero reset	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	AT Initialising the autoadaptive	Oil wear counter	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Radio Configuration	CD changer configuration	A/C Configuration	Alarm Configuration	Initialisation of autoadaptatives	Forced Regeneration Of The Particle Filter Vehicle Stationary	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes
C1	Engine ECU	Petrol engine	ME795																																			
C1	Gearbox ECU	MMT																																				
C1	Airbag	Airbag																																				
C1	ABS or ESP	ABS or ESP																																				
C1	Coded anti-start	ADC																																				
C1	Power steering	DAE																																				
C1(B4)	Engine ECU	ME17_9_52																																				
C1(B4)	ABS	RBV																																				
C1(B4)	EPS	EPS_T																																				
C1(B4)	Instrument panel	MET																																				
C1(B4)	Immobilizer	Immobilizer																																				
C2	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LPC																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	TU1A J34P																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	TU3A J34P																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM2																																			
C2	Injection	Diesel (6th to 8th digit of VIN)	9HZ(FAP) BOSCH EDC16C34 DV6TED4																																			
C2	Injection	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C34 DV4TD																																			
C2	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID806																																			
C2	Gearbox ECU	Gearbox ECU																																				
C2	Airbag	Airbag																																				
C2	Anti-lock brake system	ABS MK 70		V	V																																	
C2	Anti-lock brake system	ABS MK70.1																																				
C2	Anti-lock brake system	ESP MK60																																				
C2	Anti-lock brake system	ESP MK60-O																																				
C2	BSI	BSI																																				
C2	Instrument panel	Instrument panel				V																																
C2	Radio	Radio																																				
C2	CD player	CD player																																				
C2	Parking aid	Parking aid																																				
C2	Air conditioning	Air conditioning																																				
C2	Switch module under the steering wheel	Switch module under the steering wheel																																				
C2	Rain sensor Brightness	Rain sensor / Brightness																																				

Vehicle	System 1	System 2	System 3	Rear Right Wheel Solenoid Valve	Bleeding	Service zero reset	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	AT Initialising the autoadaptive	Oil wear counter	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Radio Configuration	CD changer configuration	A/C Configuration	Alarm Configuration	Initialisation of autoadaptatives	Forced Regeneration Of The Particle Filter Vehicle Stationary	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes
C2	Multifunction screen	Multifunction screen					V	V	V																													
C2	Electric power steering ECU	Electric power steering ECU																																				
C3	Injection	Petrol (6th to 8th digit of VIN)	HFX MM48P																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME744																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME744																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV BOSCH ME744																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM1																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM2																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 5FS																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 8FR																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 8FP																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 CV6ATED4																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C34 DV4TD																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX BOSCH EDC16C34 DV4TD																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX SIEMENS SID802																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX SIEMENS SID804																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID804																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID806																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HY DELPHI C6																																			
C3	Gearbox ECU	Auto gearbox BVA_AL4								V	V																											
C3	Gearbox ECU	Controlled manual gearbox ECU																																				
C3	Airbag	Airbag																																				
C3	Anti-lock brake system	ABS MK60		V	V																																	
C3	Anti-lock brake system	ABS MK70		V	V																																	
C3	Anti-lock brake system	ESP																																				
C3	BSI	BSI										V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
C3	Instrument panel	Instrument panel																																				
C3	Radio	Radio												V																	V							
C3	CD player	CD player																														V						
C3	Parking aid	Parking aid																																				

Vehicle	System 1	System 2	System 3	Rear Right Wheel Solenoid Valve	Bleeding	Service zero reset	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	AT Initialising the autoadaptive	Oil wear counter	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Radio Configuration	CD changer configuration	A/C Configuration	Alarm Configuration	Initialisation of autoadaptatives	Forced Regeneration Of The Particle Filter Vehicle Stationary	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes
C3	Air conditioning	Air conditioning																															V					
C3	Navigation	Navigation																																				
C3	Alarm	Alarm																																V				
C3	Switch module under the steering wheel	Switch module under the steering wheel																																				
C3	Diesel additive function	Diesel additive function																																				
C3	Rain sensor Brightness	Rain sensor / Brightness																																				
C3	Driving school mode	Driving school mode																																				
C3	Multifunction display	Multifunction display																																				
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FT MED17.4																																V			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FX MED17.4																																V			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																V			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	6FY MM6LPB																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	MM6KP Bio Flex																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 23A																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 HMU																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 HMZ																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR DELPHI DCM3.4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHF DELPHI DCM3.4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C34 DV6TED4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C34 DV6TED4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A																																	V	V	V
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	Engine type 42 : EB2DTS engine with 5-speed manual gearbox																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	Engine type 44 : EB2DTS engine with 6-speed manual gearbox																																			

Vehicle	System 1	System 2	System 3	Rear Right Wheel Solenoid Valve	Bleeding	Service zero reset	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	AT Initialising the autoadaptive	Oil wear counter	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Radio Configuration	CD changer configuration	A/C Configuration	Alarm Configuration	Initialisation of autoadaptatives	Forced Regeneration Of The Particle Filter Vehicle Stationary	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes
C3 PLURIEL	Gearbox ECU	BVA_AL4_AT8																																				
C3 PLURIEL	Gearbox ECU	Controlled manual gearbox (BVMP)																																				
C3 PLURIEL	BSI	BSI																																				
C3 PLURIEL	Airbag	Airbag																																				
C3 PLURIEL	ABS or ESP	ABS_MK70.1																																				
C3 PLURIEL	ABS or ESP	ESP MK60-O																																				
C3 PLURIEL	Instrument panel	Instrument panel				V																																
C3 PLURIEL	Radio	Radio																																				
C3 PLURIEL	Multifunction display	Multifunction display																																				
C3 PLURIEL	Power steering electric pump unit	Power steering electric pump unit																																				
C3 PLURIEL	Switch module at the steering wheel	Switch module at the steering wheel																																				
C3 PLURIEL	Sun roof	Sun roof																																				
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																V			
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FS MEV17.4																																V			
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FP MEV17.4																																V			
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FS MEV17.4.2																																V			
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FP MEV17.4.2																																V			
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FR MED17.4																																V			
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV																																			
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4- 90CV																																			
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HR HDI SID807																																			
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	EDC17C10 BR2																																			
C3 PICASSO	Gearbox ECU	BVA_AT8																																				
C3 PICASSO	Gearbox ECU	CFC300P																																				
C3 PICASSO	Gearbox ECU	BVA AM6 Euro5																																				
C3 PICASSO	BSI	BSI																																				
C3 PICASSO	Airbag	Airbag																																				
C3 PICASSO	ABS	ESP_MK60																																				
C3 PICASSO	ABS	ABS MK 70.2																																				
C3 PICASSO	Instrument panel	Instrument panel				V																																
C3 PICASSO	Parking aid	Parking aid																																				
C3 PICASSO	Air conditioning	Air conditioning																																				
C3 PICASSO	Switch module under the steering wheel	Switch module under the steering wheel																																				
C3 PICASSO	Multifunction display	Multifunction display																																				
C3 PICASSO	Multiplexed additive pump	POMPE_MUX_MGI																																				
C3 PICASSO	Electric power steering	DAE																																				

Vehicle	System 1	System 2	System 3	Rear Right Wheel Solenoid Valve	Bleeding	Service zero reset	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	AT Initialising the autoadaptive	Oil wear counter	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Radio Configuration	CD changer configuration	A/C Configuration	Alarm Configuration	Initialisation of autoadaptatives	Forced Regeneration Of The Particle Filter Vehicle Stationary	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes
C3 PICASSO	Battery charge status unit	Battery charge status unit																																				
C3 PICASSO	Engine relay unit	Engine relay unit																																				
C3 PICASSO	Trailer relay unit	Trailer relay unit																																				
C3 PICASSO	Radio	Radio																																				
C3 PICASSO	Driver's door module	Driver's door module																																				
C3 PICASSO	Rain sensor	Rain sensor																																				
C3 PICASSO	Central voltage retention device	Central voltage retention device																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	5FT MED17.4																																V			
C4	Injection	Petrol (6th to 8th digit of VIN)	5FX MED17.4																																V			
C4	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																V			
C4	Injection	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	6FY MM6LPB																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	MM6KP Bio Flex																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 23A																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 HMU																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 HMZ																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR DELPHI DCM3.4																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	RHF DELPHI DCM3.4																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C34 DV6TED4																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C34 DV6TED4																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A																																	V	V	V
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	Engine type 42 : EB2DTS engine with 5-speed manual gearbox																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	Engine type 44 : EB2DTS engine with 6-speed manual gearbox																																			
C4	Gearbox ECU	Auto gearbox AL4								V	V																											

Vehicle	System 1	System 2	System 3	Rear Right Wheel Solenoid Valve	Bleeding	Service zero reset	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	AT Initialising the autoadaptive	Oil wear counter	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Radio Configuration	CD changer configuration	A/C Configuration	Alarm Configuration	Initialisation of autoadaptatives	Forced Regeneration Of The Particle Filter Vehicle Stationary	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes
C4	Gearbox ECU	Auto gearbox AL4																																				
C4	Gearbox ECU	Auto gearbox AM6																																				
C4	Gearbox ECU	CFC300P																																				
C4	Gearbox ECU	BVA AM6 Euro5																																				
C4	BSI	BSI																																				
C4	Airbag	Airbag																																				
C4	ABS or ESP	ABS 8_Bosch																																				
C4	ABS or ESP	ESP 8_1																																				
C4	ECU at the top of the steering column	ECU at the top of the steering column																																				
C4	Instrument panel	Instrument panel				V																																
C4	Radio	Radio																																				
C4	CD player	CD player																																				
C4	Parking aid	Parking aid																																				
C4	Air conditioning	Air conditioning																																				
C4	Multifunction display	Multifunction display																																				
C4	Power steering electric pump unit	Power steering electric pump unit																																				
C4	Engine relay unit	Engine relay unit																																				
C4	Trailer relay unit	Trailer relay unit																																				
C4	Remote instrument panel unit	Remote instrument panel unit																																				
C4	Passenger door electronics	Passenger door electronics																																				
C4	Driver's door electronics	Driver's door electronics																																				
C4 II	Engine(6th to 8th digit of VIN)	MED17_4_2	5FV MED17_4_2 EURO5																																			
C4 II	Engine(6th to 8th digit of VIN)	EDC17C10 BR2																																				
C4 II	Engine(6th to 8th digit of VIN)	9HR HDI SID807																																				
C4 II	Gearbox ECU	BVA_AT8																																				
C4 II	Gearbox ECU	CFC300P																																				
C4 II	Gearbox ECU	BVA AM6 Euro5																																				
C4 II	Airbag	RBG_UDS																																				
C4 II	ABS Electronic stability program	ESP 8.1																																				
C4 II	BSI	BSI																																				
C4 II	Power steering electric pump unit	GET																																				
C4 II	Battery charge status unit	Battery charge status unit																																				
C4 II	Engine relay unit	Engine relay unit																																				
C4 II	Display	Display																																				
C4 II	Driver's door module	Driver's door module																																				
C4 II	Electric secondary brake	Electric secondary brake																																				

Vehicle	System 1	System 2	System 3	Rear Right Wheel Solenoid Valve	Bleeding	Service zero reset	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	AT Initialising the autoadaptive	Oil wear counter	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilation	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Radio Configuration	CD changer configuration	A/C Configuration	Alarm Configuration	Initialisation of autoadaptatives	Forced Regeneration Of The Particle Filter Vehicle Stationary	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes
C4 II	Trailer relay unit	Trailer relay unit																																				
C4 II	Seat belts not fastened LED unit	Seat belts not fastened LED unit																																				
C4 II	Multiplexed control panel	Multiplexed control panel																																				
C4 II	Controls on the steering wheel	Controls on the steering wheel																																				
C4 II	Supply protection and management unit	Supply protection and management unit																																				
C4 II	Windscreen wiper	Windscreen wiper																																				
C4 II	Switch module at the steering wheel	Switch module at the steering wheel																																				
C4 II	Heatingventilation	Heating/ventilation																																				
C4 II	Instrument panel	Instrument panel																																				
C4 II	Radio or radiotelephone	Radio or radiotelephone																																				
C4 II	Passenger door electronics	Passenger door electronics																																				
C4 II	Rain and brightness sensor	Rain and brightness sensor																																				
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FT MED17.4																															V			
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FX MED17.4																															V			
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																															V			
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB																																		
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	6FY MM6LPB																																		
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FV MED17_4_2																																		
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HZ(FAP) BOSCH EDC16C34 DV6TED4																																		
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A																																V	V	V
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	RHJ SIEMENS SID803A																																V	V	V
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HR HDI SID807																																		
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HL - DV6CTED - 111 CV HDI_SID807_BR2																																		
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HR - DV6CTED - 111 CV HDI_SID807_BR2																																		
C4 PICASSO	Gearbox ECU	Auto gearbox AL4																																				
C4 PICASSO	Gearbox ECU	Auto gearbox AL4								V	V																											
C4 PICASSO	Gearbox ECU	Auto gearbox AM6																																				
C4 PICASSO	Gearbox ECU	CFC300P																																				
C4 PICASSO	Gearbox ECU	BVA AM6 Euro5																																				
C4 PICASSO	Driver and passenger airbags	Driver and passenger airbags																																				
C4 PICASSO	ABS Electronic stability program	ESP 8.1																																				
C4 PICASSO	ABS Electronic stability program	90 ESP			V																																	
C4 PICASSO	BSI	BSI																																				
C4 PICASSO	Power steering electric pump unit(GEP)	Power steering electric pump unit(GEP)																																				
C4 PICASSO	Power steering electric pump unit(GEP)	Power steering electric pump unit(GEP)																																				
C4 PICASSO	Battery charge status unit	Battery charge status unit																																				

Vehicle	System 1	System 2	System 3	Rear Right Wheel Solenoid Valve	Bleeding	Service zero reset	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	AT Initialising the autoadaptive	Oil wear counter	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Radio Configuration	CD changer configuration	A/C Configuration	Alarm Configuration	Initialisation of autoadaptatives	Forced Regeneration Of The Particle Filter Vehicle Stationary	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes
C4 PICASSO	Electric secondary brake	Electric secondary brake																																				
C4 PICASSO	Engine relay unit	Engine relay unit																																				
C4 PICASSO	Trailer relay unit	Trailer relay unit																																				
C4 PICASSO	Windscreen wiper	Windscreen wiper																																				
C4 PICASSO	ECU at the top of the steering column	ECU at the top of the steering column																																				
C4 PICASSO	Heatingventilation	Heating/ventilation																																				
C4 PICASSO	Instrument panel	Instrument panel				V																																
C4 PICASSO	Radio or radiotelephone	Radio or radiotelephone																																				
C4 PICASSO	Passenger door electronics	Passenger door electronics																																				
C4 PICASSO	Passenger door electronics	Passenger door electronics																																				
C4 PICASSO	Driver's door electronics	Driver's door electronics																																				
C4 PICASSO	Driver's door electronics	Driver's door electronics																																				
C4 PICASSO	Rain and brightness sensor	Rain and brightness sensor																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																		V		
C4 Cactus	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	DCM3.5_BR2																																		V		
C4 Cactus	Engine(6th to 8th digit of VIN)	SID807																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																	V			
C4 Cactus	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																	V			
C4 Cactus	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																	V			
C4 Cactus	Engine(6th to 8th digit of VIN)	MED17_4_4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																				
C4 Cactus	Gearbox ECU	AM6 Euro5 automatic gearbox																																				
C4 Cactus	Gearbox ECU	AT6 Euro5 automatic gearbox																																				
C4 Cactus	Gearbox ECU	CFC300P gearbox																																				
C4 Cactus	Gearbox ECU	AL4 automatic gearbox																																				
C4 Cactus	Gearbox ECU	BVA_AM6_AT6_UDS																																				
C4 Cactus	Multiplexed additive adding pump ECU	Multiplexed additive adding pump ECU																																				
C4 Cactus	ABS or ESP ECU	ESP 81																																				
C4 Cactus	ABS or ESP ECU	ESP MK 100																																				

Vehicle	System 1	System 2	System 3	Rear Right Wheel Solenoid Valve	Bleeding	Service zero reset	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	AT Initialising the autoadaptive	Oil wear counter	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Radio Configuration	CD changer configuration	A/C Configuration	Alarm Configuration	Initialisation of autoadaptatives	Forced Regeneration Of The Particle Filter Vehicle Stationary	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes
C4 Cactus	ABS or ESP ECU	90 ESP			V																																	
C4 Cactus	Headlamp height adjuster directional headlamp	Headlamp height adjuster/ directional headlamp																																				
C4 Cactus	Built-In system interface	Built-In system interface																																				
C4 Cactus	Built-In system interface	Built-In system interface																																				
C4 Cactus	Power steering electric pump unit	GEP																																				
C4 Cactus	Power steering electric pump unit	DAE_BVH2																																				
C4 Cactus	Battery charge status unit	BECB_GEN2																																				
C4 Cactus	Electric secondary brake	FSE																																				
C4 Cactus	Engine relay unit	BSM																																				
C4 Cactus	Trailer relay unit	BSR																																				
C4 Cactus	Airbag ECU	RBG_UDS																																				
C4 Cactus	Airbag ECU	RBG_UDS																																				
C4 Cactus	Airbag ECU	SAC_AUTOLIV																																				
C4 Cactus	Instrument panel	COMBINE																																				
C4 Cactus	Instrument panel	COMBINE				V																																
C4 Cactus	Rain-sunlight sensor	Rain and brightness sensor																																				
C4 Cactus	Rain-sunlight sensor	CDPL_UDS_HELLA																																				
C4 Cactus	Switch module at the steering wheel	COM2008P																																				
C4 Cactus	Switch module at the steering wheel	HDC																																				
C4 Cactus	Bodywork conversion unit	BTC																																				
C4 Cactus	Parking aid	AAS																																				
C4 Cactus	Additional heating	CHAUFF_ADD																																				
C4 Cactus	Telematics unit	SMEG_PLUS																																				
C4 Cactus	Anti-theft alarm	ALARME																																				
C4 Cactus	Rear air conditioning table	TAB_CLIM_AR																																				
C4 Cactus	Rain and brightness sensor	PLUIE_LUMINOSITE																																				
C4 Cactus	Supply protection and management unit	BPGA2010																																				
C4 Cactus	Door control pad	PDPC_UDS																																				
C4 Cactus	Air conditioning	BCC																																				
C4 Cactus	Touch screen	Touch screen																																				
C4 Cactus	Seat belts not fastened LED unit	TNB_2010																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	MED17_4_2	5FV MED17_4_2 EURO5																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																		V		
C-ELYSEE	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	DCM3.5_BR2																																		V		
C-ELYSEE	Engine(6th to 8th digit of VIN)	SID807																																				

Vehicle	System 1	System 2	System 3	Rear Right Wheel Solenoid Valve	Bleeding	Service zero reset	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	AT Initialising the autoadaptive	Oil wear counter	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Radio Configuration	CD changer configuration	A/C Configuration	Alarm Configuration	Initialisation of autoadaptatives	Forced Regeneration Of The Particle Filter Vehicle Stationary	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes
C-ELYSEE	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																	V			
C-ELYSEE	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																	V			
C-ELYSEE	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																	V			
C-ELYSEE	Engine(6th to 8th digit of VIN)	MED17_4_4																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																				
C-ELYSEE	Gearbox ECU	BVA_AT8																																				
C-ELYSEE	Gearbox ECU	CFC300P																																				
C-ELYSEE	Gearbox ECU	BVA AM6 Euro5																																				
C-ELYSEE	Airbag	RBG_UDS																																				
C-ELYSEE	ABS_Electronic stability program	ESP 8.1																																				
C-ELYSEE	ABS_Electronic stability program	ABS 81																																				
C-ELYSEE	BSI	BSI2010																																				
C-ELYSEE	Power steering electric pump unit	GET																																				
C-ELYSEE	Battery charge status unit	Battery charge status unit																																				
C-ELYSEE	Electric secondary brake	Electric secondary brake																																				
C-ELYSEE	Trailer relay unit	Trailer relay unit																																				
C-ELYSEE	Windscreen wiper	Windscreen wiper																																				
C-ELYSEE	Switch module at the steering wheel	Switch module at the steering wheel																																				
C-ELYSEE	Heatingventilation	Heating/ventilation																																				
C-ELYSEE	Instrument panel	Instrument panel																																				
C-ELYSEE	Radio or radiotelephone	Radio or radiotelephone																																				
C-ELYSEE	Passenger door electronics	Passenger door electronics																																				
C-ELYSEE	Rain and brightness sensor	Rain and brightness sensor																																				
JUMPY	Injection(6th to 8th digit of VIN)	EDC16C3	9HU-DV6UTED4 - 90 CV																																			
JUMPY	Injection(6th to 8th digit of VIN)	DCM3.5_BR2	AHZ-DW10CD-128CV																																	V		V
JUMPY	Anti-lock brake system	ABS 8.1																																				
JUMPY	Airbag	Airbag																																				
JUMPY	Trailer relay unit	Trailer relay unit																																				
JUMPY	Engine relay unit	Engine relay unit																																				
JUMPY	BSI	BSI																																				

Vehicle	System 1	System 2	System 3	Rear Right Wheel Solenoid Valve	Bleeding	Service zero reset	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	AT Initialising the autoadaptive	Oil wear counter	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Radio Configuration	CD changer configuration	A/C Configuration	Alarm Configuration	Initialisation of autoadaptatives	Forced Regeneration Of The Particle Filter Vehicle Stationary	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes
JUMPY	Switch module under the steering wheel	Switch module under the steering wheel																																				
JUMPY	Bodywork conversion unit	Bodywork conversion unit																																				
Jumper	Engine(6th to 8th digit of VIN) Gearbox	PUMA	PUMA 4HV																																			
Jumper	Engine(6th to 8th digit of VIN) Gearbox	PUMA	PUMA 4HU(120 or 130)																																			
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC16C39	EDC16C39 TUB																																			
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52	EDC17CP52 SOFIM EURO5																																			
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52_UDS 3.0 HDI 180CV E5	EDC17CP52_UDS 3.0 HDI 180CV E5																																			
Jumper	Engine(6th to 8th digit of VIN) Gearbox	SID208	SID208																																			
Jumper	ABSESP	ESP90_F																																				
Jumper	Power steering	SSCU																																				
Jumper	Airbag	Airbag																																				
Jumper	Built-In system interface	Built-In system interface																																				
Jumper	Built-In system interface	Built-In system interface																																				
Berlingo	Driving assistance Comfort	Parking aid																																				
Berlingo	Built-In system interface	Built-In system interface																																				
Berlingo	Driver information Communication	Display / Telematics																																				
Berlingo	Driver information Communication	Radio												V																	V							
Berlingo	Driver information Communication	CD Player																														V						
Berlingo	Driver information Communication	Instrument panel																																				
Berlingo	Driver information Communication	Switching module below steering wheel (COM 2000)																																				
Berlingo	Airbags	Airbags																																				
Berlingo	VisibilityLighting	Switching module below steering wheel (COM 2000)																																				
Berlingo	VisibilityLighting	Rain/sunlight sensor																																				
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P																																			
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																			
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																			
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																			
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P																																			
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801																																			
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2																																			
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																			
Berlingo	Active Safety	ESP BOSCH 5.7																																				
Berlingo	Active Safety	ABS BOSCH 8																																				
Berlingo	Active Safety	ESP BOSCH 8																																				
Berlingo	Active Safety	ABS 8.1																																				
Berlingo	Active Safety	ESP 8.1																																				

Vehicle	System 1	System 2	System 3	Rear Right Wheel Solenoid Valve	Bleeding	Service zero reset	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	AT Initialising the autoadaptive	Oil wear counter	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Radio Configuration	CD changer configuration	A/C Configuration	Alarm Configuration	Initialisation of autoadaptatives	Forced Regeneration Of The Particle Filter Vehicle Stationary	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HW DV6BTED4 - 75 CV																																			
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HX DV6AUTED4 - 90 CV																																V		V
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HX-DV6ATED4 - 90 CV																																V		V
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HZ-DV6TED4 FAP - 110 CV																																V		V
Berlingo II	Injection(6th to 8th digit of VIN)	EDC17C10 BR2	9HN-DV6ETED																																V		
Berlingo II	Anti-lock brake system	ABS 8																																			
Berlingo II	Anti-lock brake system	ESP8.1_BOSCH																																			
Berlingo II	Anti-lock brake system	ABS 81																																			
Berlingo II	Airbag	Airbag																																			
Berlingo II	Power steering electric pump unit	Power steering electric pump unit																																			
Berlingo II	Instrument panel	Instrument panel																																			
Berlingo II	Radio	RD4																																			
Berlingo II	Radio	RD45																																			
Berlingo II	Rain sensor Brightness	Rain sensor / Brightness																																			
Berlingo II	Trailer relay unit	Trailer relay unit																																			
Berlingo II	Engine relay unit	Engine relay unit																																			
Berlingo II	Multiplexed additive pump	Multiplexed additive pump																																			
Berlingo II	Multifunction display	Multifunction display																																			
Berlingo II	BSI	BSI																V																			
Berlingo II	Switch module under the steering wheel	Switch module under the steering wheel																																			
Berlingo II	Switch module under the steering wheel	Switch module under the steering wheel																																			
NEMO	Engine(6th to 8th digit of VIN) Gearbox	EDC16C34																																			
NEMO	Engine(6th to 8th digit of VIN) Gearbox	HDI_8DF3																																			
NEMO	Engine(6th to 8th digit of VIN) Gearbox	BMF PUMA	BMF HDI 4C																																		
NEMO	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52_UDS 3.0 HDI 180CV E5																																			
NEMO	Engine(6th to 8th digit of VIN) Gearbox	SID208																																			
NEMO	ABSESP	ESP 90_F																																			
NEMO	ABSESP	ESP 81																																			
NEMO	ABSESP	ABS 81																																			
NEMO	Built-In system interface	Built-In system interface																																			
NEMO	Built-In system interface	Built-In system interface																																			
NEMO	Built-In system interface	Built-In system interface																																			
NEMO	Airbag	Airbag																																			
NEMO	LDWS	LDWS																																			
NEMO	Instrument	Instrument																																			
NEMO	Parking control	Parking control																																			

Vehicle	System 1	System 2	System 3	Replacement Of The Particle Emission Filter	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Replacement of the additive tank	Replacement of the additive pump	Reset to zero of the counter for the number of restarts	Brake cable replacement	Electric parking brake replacement	Calibration of the steering wheel angle sensor	Longitudinal acceleration sensor calibration	Replacement of the brake pads	Replacement of the brake pads	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes
C1	Engine ECU	Petrol engine	ME795																																			
C1	Gearbox ECU	MMT																																				
C1	Airbag	Airbag																																				
C1	ABS or ESP	ABS or ESP																																				
C1	Coded anti-start	ADC																																				
C1	Power steering	DAE																																				
C1(B4)	Engine ECU	ME17_9_52																																				
C1(B4)	ABS	RBV																																				
C1(B4)	EPS	EPS_T																																				
C1(B4)	Instrument panel	MET																																				
C1(B4)	Immobilizer	Immobilizer																																				
C2	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LPC																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	TU1A J34P																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	TU3A J34P																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM2																																			
C2	Injection	Diesel (6th to 8th digit of VIN)	9HZ(FAP) BOSCH EDC16C34 DV6TED4																																			
C2	Injection	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C34 DV4TD																																			
C2	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID806																																			
C2	Gearbox ECU	Gearbox ECU																																				
C2	Airbag	Airbag																																				
C2	Anti-lock brake system	ABS MK 70																																				
C2	Anti-lock brake system	ABS MK70.1																																				
C2	Anti-lock brake system	ESP MK60																																				
C2	Anti-lock brake system	ESP MK60-O																																				
C2	BSI	BSI																																				
C2	Instrument panel	Instrument panel																																				
C2	Radio	Radio																																				
C2	CD player	CD player																																				
C2	Parking aid	Parking aid																																				
C2	Air conditioning	Air conditioning																																				
C2	Switch module under the steering wheel	Switch module under the steering wheel																																				
C2	Rain sensor Brightness	Rain sensor / Brightness																																				

Vehicle	System 1	System 2	System 3	Replacement Of The Particle Emission Filter	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Replacement of the additive tank	Replacement of the additive pump	Reset to zero of the counter for the number of restarts	Brake cable replacement	Electric parking brake replacement	Calibration of the steering wheel angle sensor	Longitudinal acceleration sensor calibration	Replacement of the brake pads	Replacement of the brake pads	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB functio	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes
C2	Multifunction screen	Multifunction screen																																				
C2	Electric power steering ECU	Electric power steering ECU																																				
C3	Injection	Petrol (6th to 8th digit of VIN)	HFX MM48P																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME744																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME744																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV BOSCH ME744																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM1																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM2																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 5FS																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 8FR																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 8FP																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 CV6ATED4																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C34 DV4TD																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX BOSCH EDC16C34 DV4TD																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX SIEMENS SID802																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX SIEMENS SID804																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID804																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID806																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HY DELPHI C6																																			
C3	Gearbox ECU	Auto gearbox BVA_AL4																																				
C3	Gearbox ECU	Controlled manual gearbox ECU																																				
C3	Airbag	Airbag																																				
C3	Anti-lock brake system	ABS MK60																																				
C3	Anti-lock brake system	ABS MK70																																				
C3	Anti-lock brake system	ESP																																				
C3	BSI	BSI																																				
C3	Instrument panel	Instrument panel																																				
C3	Radio	Radio																																				
C3	CD player	CD player																																				
C3	Parking aid	Parking aid																																				

Vehicle	System 1	System 2	System 3	Replacement Of The Particle Emission Filter	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Replacement of the additive tank	Replacement of the additive pump	Reset to zero of the counter for the number of restarts	Brake cable replacement	Electric parking brake replacement	Calibration of the steering wheel angle sensor	Longitudinal acceleration sensor calibration	Replacement of the brake pads	Replacement of the brake pads	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes
C3	Air conditioning	Air conditioning																																				
C3	Navigation	Navigation																																				
C3	Alarm	Alarm																																				
C3	Switch module under the steering wheel	Switch module under the steering wheel																																				
C3	Diesel additive function	Diesel additive function																																				
C3	Rain sensor Brightness	Rain sensor / Brightness																																				
C3	Driving school mode	Driving school mode																																				
C3	Multifunction display	Multifunction display																																				
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FT MED17.4																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FX MED17.4																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	6FY MM6LPB																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	MM6KP Bio Flex																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 23A																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 HMU																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 HMZ																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR DELPHI DCM3.4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHF DELPHI DCM3.4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C34 DV6TED4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C34 DV6TED4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A	V																																		
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	Engine type 42 : EB2DTS engine with 5-speed manual gearbox																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	Engine type 44 : EB2DTS engine with 6-speed manual gearbox																																			

Vehicle	System 1	System 2	System 3	Replacement Of The Particle Emission Filter	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Replacement of the additive tank	Replacement of the additive pump	Reset to zero of the counter for the number of restarts	Brake cable replacement	Electric parking brake replacement	Calibration of the steering wheel angle sensor	Longitudinal acceleration sensor calibration	Replacement of the brake pads	Replacement of the brake pads	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes
C3 PLURIEL	Gearbox ECU	BVA_AL4_AT8																																					
C3 PLURIEL	Gearbox ECU	Controlled manual gearbox (BVMP)																																					
C3 PLURIEL	BSI	BSI																																					
C3 PLURIEL	Airbag	Airbag																																					
C3 PLURIEL	ABS or ESP	ABS_MK70.1																																					
C3 PLURIEL	ABS or ESP	ESP MK60-O																																					
C3 PLURIEL	Instrument panel	Instrument panel																																					
C3 PLURIEL	Radio	Radio																																					
C3 PLURIEL	Multifunction display	Multifunction display			V	V	V	V	V																														
C3 PLURIEL	Power steering electric pump unit	Power steering electric pump unit																																					
C3 PLURIEL	Switch module at the steering wheel	Switch module at the steering wheel																																					
C3 PLURIEL	Sun roof	Sun roof																																					
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																				
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FS MEV17.4																																				
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FP MEV17.4																																				
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FS MEV17.4.2																																				
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FP MEV17.4.2																																				
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FR MED17.4																																				
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV																																				
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4- 90CV																																				
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HR HDI SID807																																				
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	EDC17C10 BR2																																				
C3 PICASSO	Gearbox ECU	BVA_AT8																																					
C3 PICASSO	Gearbox ECU	CFC300P																																					
C3 PICASSO	Gearbox ECU	BVA AM6 Euro5																																					
C3 PICASSO	BSI	BSI																																					
C3 PICASSO	Airbag	Airbag																																					
C3 PICASSO	ABS	ESP_MK60																																					
C3 PICASSO	ABS	ABS MK 70.2																																					
C3 PICASSO	Instrument panel	Instrument panel																																					
C3 PICASSO	Parking aid	Parking aid																																					
C3 PICASSO	Air conditioning	Air conditioning																																					
C3 PICASSO	Switch module under the steering wheel	Switch module under the steering wheel																																					
C3 PICASSO	Multifunction display	Multifunction display			V	V	V	V	V																														
C3 PICASSO	Multiplexed additive pump	POMPE_MUX_MGI								V	V																												
C3 PICASSO	Electric power steering	DAE																																					

Vehicle	System 1	System 2	System 3	Replacement Of The Particle Emission Filter	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Replacement of the additive tank	Replacement of the additive pump	Reset to zero of the counter for the number of restarts	Brake cable replacement	Electric parking brake replacement	Calibration of the steering wheel angle sensor	Longitudinal acceleration sensor calibration	Replacement of the brake pads	Replacement of the brake pads	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes
C3 PICASSO	Battery charge status unit	Battery charge status unit																																					
C3 PICASSO	Engine relay unit	Engine relay unit																																					
C3 PICASSO	Trailer relay unit	Trailer relay unit																																					
C3 PICASSO	Radio	Radio																																					
C3 PICASSO	Driver's door module	Driver's door module																																					
C3 PICASSO	Rain sensor	Rain sensor																																					
C3 PICASSO	Central voltage retention device	Central voltage retention device																																					
C4	Injection	Petrol (6th to 8th digit of VIN)	5FT MED17.4																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	5FX MED17.4																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	6FY MM6LPB																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	MM6KP Bio Flex																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 23A																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 HMU																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 HMZ																																				
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR DELPHI DCM3.4																																				
C4	Injection	Diesel (6th to 8th digit of VIN)	RHF DELPHI DCM3.4																																				
C4	Injection	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C34 DV6TED4																																				
C4	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4																																				
C4	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4																																				
C4	Injection	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C34 DV6TED4																																				
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A	V																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803																																				
C4	Injection	Diesel (6th to 8th digit of VIN)	Engine type 42 : EB2DTS engine with 5-speed manual gearbox																																				
C4	Injection	Diesel (6th to 8th digit of VIN)	Engine type 44 : EB2DTS engine with 6-speed manual gearbox																																				
C4	Gearbox ECU	Auto gearbox AL4																																					

Vehicle	System 1	System 2	System 3	Replacement Of The Particle Emission Filter	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Replacement of the additive tank	Replacement of the additive pump	Reset to zero of the counter for the number of restarts	Brake cable replacement	Electric parking brake replacement	Calibration of the steering wheel angle sensor	Longitudinal acceleration sensor calibration	Replacement of the brake pads	Replacement of the brake pads	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB functio	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes
C4	Gearbox ECU	Auto gearbox AL4																																				
C4	Gearbox ECU	Auto gearbox AM6																																				
C4	Gearbox ECU	CFC300P																																				
C4	Gearbox ECU	BVA AM6 Euro5																																				
C4	BSI	BSI																																				
C4	Airbag	Airbag																																				
C4	ABS or ESP	ABS 8_Bosch																																				
C4	ABS or ESP	ESP 8_1																																				
C4	ECU at the top of the steering column	ECU at the top of the steering column																																				
C4	Instrument panel	Instrument panel																																				
C4	Radio	Radio																																				
C4	CD player	CD player																																				
C4	Parking aid	Parking aid																																				
C4	Air conditioning	Air conditioning																																				
C4	Multifunction display	Multifunction display			V	V	V	V	V																													
C4	Power steering electric pump unit	Power steering electric pump unit																																				
C4	Engine relay unit	Engine relay unit																																				
C4	Trailer relay unit	Trailer relay unit																																				
C4	Remote instrument panel unit	Remote instrument panel unit																																				
C4	Passenger door electronics	Passenger door electronics																																				
C4	Driver's door electronics	Driver's door electronics																																				
C4 II	Engine(6th to 8th digit of VIN)	MED17_4_2	5FV MED17_4_2 EURO5																																			
C4 II	Engine(6th to 8th digit of VIN)	EDC17C10 BR2																																				
C4 II	Engine(6th to 8th digit of VIN)	9HR HDI SID807																																				
C4 II	Gearbox ECU	BVA_AT8																																				
C4 II	Gearbox ECU	CFC300P																																				
C4 II	Gearbox ECU	BVA AM6 Euro5																																				
C4 II	Airbag	RBG_UDS																																				
C4 II	ABS Electronic stability program	ESP 8.1																																				
C4 II	BSI	BSI										V																										
C4 II	Power steering electric pump unit	GET																																				
C4 II	Battery charge status unit	Battery charge status unit																																				
C4 II	Engine relay unit	Engine relay unit																																				
C4 II	Display	Display																																				
C4 II	Driver's door module	Driver's door module																																				
C4 II	Electric secondary brake	Electric secondary brake											V	V																								

Vehicle	System 1	System 2	System 3	Replacement Of The Particle Emission Filter	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Replacement of the additive tank	Replacement of the additive pump	Reset to zero of the counter for the number of restarts	Brake cable replacement	Electric parking brake replacement	Calibration of the steering wheel angle sensor	Longitudinal acceleration sensor calibration	Replacement of the brake pads	Replacement of the brake pads	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes
C4 II	Trailer relay unit	Trailer relay unit																																					
C4 II	Seat belts not fastened LED unit	Seat belts not fastened LED unit																																					
C4 II	Multiplexed control panel	Multiplexed control panel																																					
C4 II	Controls on the steering wheel	Controls on the steering wheel																																					
C4 II	Supply protection and management unit	Supply protection and management unit																																					
C4 II	Windscreen wiper	Windscreen wiper																																					
C4 II	Switch module at the steering wheel	Switch module at the steering wheel																																					
C4 II	Heatingventilation	Heating/ventilation																																					
C4 II	Instrument panel	Instrument panel																																					
C4 II	Radio or radiotelephone	Radio or radiotelephone																																					
C4 II	Passenger door electronics	Passenger door electronics																																					
C4 II	Rain and brightness sensor	Rain and brightness sensor																																					
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FT MED17.4																																				
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FX MED17.4																																				
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																				
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB																																				
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	6FY MM6LPB																																				
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FV MED17_4_2																																				
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HZ(FAP) BOSCH EDC16C34 DV6TED4																																				
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A	V																																			
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	RHJ SIEMENS SID803A	V																																			
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HR HDI SID807																																				
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HL - DV6CTED - 111 CV HDI_SID807_BR2																																				
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HR - DV6CTED - 111 CV HDI_SID807_BR2																																				
C4 PICASSO	Gearbox ECU	Auto gearbox AL4																																					
C4 PICASSO	Gearbox ECU	Auto gearbox AL4																																					
C4 PICASSO	Gearbox ECU	Auto gearbox AM6																																					
C4 PICASSO	Gearbox ECU	CFC300P																																					
C4 PICASSO	Gearbox ECU	BVA AM6 Euro5																																					
C4 PICASSO	Driver and passenger airbags	Driver and passenger airbags																																					
C4 PICASSO	ABS Electronic stability program	ESP 8.1																																					
C4 PICASSO	ABS Electronic stability program	90 ESP													V	V	V	V	V	V	V	V	V	V	V														
C4 PICASSO	BSI	BSI										V																											
C4 PICASSO	Power steering electric pump unit(GEP)	Power steering electric pump unit(GEP)																																					
C4 PICASSO	Power steering electric pump unit(GEP)	Power steering electric pump unit(GEP)																																					
C4 PICASSO	Battery charge status unit	Battery charge status unit																																					

Vehicle	System 1	System 2	System 3	Replacement Of The Particle Emission Filter	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Replacement of the additive tank	Replacement of the additive pump	Reset to zero of the counter for the number of restarts	Brake cable replacement	Electric parking brake replacement	Calibration of the steering wheel angle sensor	Longitudinal acceleration sensor calibration	Replacement of the brake pads	Replacement of the brake pads	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB functio	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes
C4 PICASSO	Electric secondary brake	Electric secondary brake											V	V																								
C4 PICASSO	Engine relay unit	Engine relay unit																																				
C4 PICASSO	Trailer relay unit	Trailer relay unit																																				
C4 PICASSO	Windscreen wiper	Windscreen wiper																																				
C4 PICASSO	ECU at the top of the steering column	ECU at the top of the steering column																																				
C4 PICASSO	Heatingventilation	Heating/ventilation																																				
C4 PICASSO	Instrument panel	Instrument panel																																				
C4 PICASSO	Radio or radiotelephone	Radio or radiotelephone																																				
C4 PICASSO	Passenger door electronics	Passenger door electronics																																				
C4 PICASSO	Passenger door electronics	Passenger door electronics																																				
C4 PICASSO	Driver's door electronics	Driver's door electronics																																				
C4 PICASSO	Driver's door electronics	Driver's door electronics																																				
C4 PICASSO	Rain and brightness sensor	Rain and brightness sensor																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	EDC17C10_BR2		V																						V	V	V	V	V	V	V	V	V	V	V		
C4 Cactus	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	DCM3.5_BR2																																			V	V
C4 Cactus	Engine(6th to 8th digit of VIN)	SID807																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	MED17_4_4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																				
C4 Cactus	Gearbox ECU	AM6 Euro5 automatic gearbox																																				
C4 Cactus	Gearbox ECU	AT6 Euro5 automatic gearbox																																				
C4 Cactus	Gearbox ECU	CFC300P gearbox																																				
C4 Cactus	Gearbox ECU	AL4 automatic gearbox																																				
C4 Cactus	Gearbox ECU	BVA_AM6_AT6_UDS																																				
C4 Cactus	Multiplexed additive adding pump ECU	Multiplexed additive adding pump ECU																																				
C4 Cactus	ABS or ESP ECU	ESP 81													V																							
C4 Cactus	ABS or ESP ECU	ESP MK 100																																				

Vehicle	System 1	System 2	System 3	Replacement Of The Particle Emission Filter	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Replacement of the additive tank	Replacement of the additive pump	Reset to zero of the counter for the number of restarts	Brake cable replacement	Electric parking brake replacement	Calibration of the steering wheel angle sensor	Longitudinal acceleration sensor calibration	Replacement of the brake pads	Replacement of the brake pads	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB functio	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes
C4 Cactus	ABS or ESP ECU	90 ESP													V	V	V	V	V	V	V	V	V	V	V													
C4 Cactus	Headlamp height adjuster directional headlamp	Headlamp height adjuster/ directional headlamp																																				
C4 Cactus	Built-In system interface	Built-In system interface										V																										
C4 Cactus	Built-In system interface	Built-In system interface																																				
C4 Cactus	Power steering electric pump unit	GEP																																				
C4 Cactus	Power steering electric pump unit	DAE_BVH2																																				
C4 Cactus	Battery charge status unit	BECB_GEN2																																				
C4 Cactus	Electric secondary brake	FSE											V	V																								
C4 Cactus	Engine relay unit	BSM																																				
C4 Cactus	Trailer relay unit	BSR																																				
C4 Cactus	Airbag ECU	RBG_UDS																																				
C4 Cactus	Airbag ECU	RBG_UDS																																				
C4 Cactus	Airbag ECU	SAC_AUTOLIV																																				
C4 Cactus	Instrument panel	COMBINE																																				
C4 Cactus	Instrument panel	COMBINE																																				
C4 Cactus	Rain-sunlight sensor	Rain and brightness sensor																																				
C4 Cactus	Rain-sunlight sensor	CDPL_UDS_HELLA																																				
C4 Cactus	Switch module at the steering wheel	COM2008P																																				
C4 Cactus	Switch module at the steering wheel	HDC																																				
C4 Cactus	Bodywork conversion unit	BTC																																				
C4 Cactus	Parking aid	AAS																																				
C4 Cactus	Additional heating	CHAUFF_ADD																																				
C4 Cactus	Telematics unit	SMEG_PLUS																																				
C4 Cactus	Anti-theft alarm	ALARME																																				
C4 Cactus	Rear air conditioning table	TAB_CLIM_AR																																				
C4 Cactus	Rain and brightness sensor	PLUIE_LUMINOSITE																																				
C4 Cactus	Supply protection and management unit	BPGA2010																																				
C4 Cactus	Door control pad	PDPC_UDS																																				
C4 Cactus	Air conditioning	BCC																																				
C4 Cactus	Touch screen	Touch screen																																				
C4 Cactus	Seat belts not fastened LED unit	TNB_2010																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	MED17_4_2	5FV MED17_4_2 EURO5																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	EDC17C10_BR2		V																						V	V	V	V	V	V	V	V	V	V	V		
C-ELYSEE	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	DCM3.5_BR2																																			V	V
C-ELYSEE	Engine(6th to 8th digit of VIN)	SID807																																				

Vehicle	System 1	System 2	System 3	Replacement Of The Particle Emission Filter	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Replacement of the additive tank	Replacement of the additive pump	Reset to zero of the counter for the number of restarts	Brake cable replacement	Electric parking brake replacement	Calibration of the steering wheel angle sensor	Longitudinal acceleration sensor calibration	Replacement of the brake pads	Replacement of the brake pads	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB functio	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes
C-ELYSEE	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	MED17_4_4																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																				
C-ELYSEE	Gearbox ECU	BVA_AT8																																				
C-ELYSEE	Gearbox ECU	CFC300P																																				
C-ELYSEE	Gearbox ECU	BVA AM6 Euro5																																				
C-ELYSEE	Airbag	RBG_UDS																																				
C-ELYSEE	ABS_Electronic stability program	ESP 8.1																																				
C-ELYSEE	ABS_Electronic stability program	ABS 81																																				
C-ELYSEE	BSI	BSI2010										V																										
C-ELYSEE	Power steering electric pump unit	GET																																				
C-ELYSEE	Battery charge status unit	Battery charge status unit																																				
C-ELYSEE	Electric secondary brake	Electric secondary brake											V	V																								
C-ELYSEE	Trailer relay unit	Trailer relay unit																																				
C-ELYSEE	Windscreen wiper	Windscreen wiper																																				
C-ELYSEE	Switch module at the steering wheel	Switch module at the steering wheel																																				
C-ELYSEE	Heatingventilation	Heating/ventilation																																				
C-ELYSEE	Instrument panel	Instrument panel																																				
C-ELYSEE	Radio or radiotelephone	Radio or radiotelephone																																				
C-ELYSEE	Passenger door electronics	Passenger door electronics																																				
C-ELYSEE	Rain and brightness sensor	Rain and brightness sensor																																				
JUMPY	Injection(6th to 8th digit of VIN)	EDC16C3	9HU-DV6UTED4 - 90 CV																																			
JUMPY	Injection(6th to 8th digit of VIN)	DCM3.5_BR2	AHZ-DW10CD-128CV	V																						V	V	V	V	V	V	V	V	V	V	V		
JUMPY	Anti-lock brake system	ABS 8.1																																				
JUMPY	Airbag	Airbag																																				
JUMPY	Trailer relay unit	Trailer relay unit																																				
JUMPY	Engine relay unit	Engine relay unit																																				
JUMPY	BSI	BSI																																				

Vehicle	System 1	System 2	System 3	Replacement Of The Particle Emission Filter	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Replacement of the additive tank	Replacement of the additive pump	Reset to zero of the counter for the number of restarts	Brake cable replacement	Electric parking brake replacement	Calibration of the steering wheel angle sensor	Longitudinal acceleration sensor calibration	Replacement of the brake pads	Replacement of the brake pads	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB functio	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes
JUMPY	Switch module under the steering wheel	Switch module under the steering wheel																																					
JUMPY	Bodywork conversion unit	Bodywork conversion unit																																					
Jumper	Engine(6th to 8th digit of VIN) Gearbox	PUMA	PUMA 4HV																																				
Jumper	Engine(6th to 8th digit of VIN) Gearbox	PUMA	PUMA 4HU(120 or 130)																																				
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC16C39	EDC16C39 TUB																																				
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52	EDC17CP52 SOFIM EURO5																																				
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52_UDS 3.0 HDI 180CV E5	EDC17CP52_UDS 3.0 HDI 180CV E5	V																																			
Jumper	Engine(6th to 8th digit of VIN) Gearbox	SID208	SID208	V																																			
Jumper	ABSESP	ESP90_F																																					
Jumper	Power steering	SSCU																																					
Jumper	Airbag	Airbag																																					
Jumper	Built-In system interface	Built-In system interface																																					
Jumper	Built-In system interface	Built-In system interface																																					
Berlingo	Driving assistance Comfort	Parking aid																																					
Berlingo	Built-In system interface	Built-In system interface																																					
Berlingo	Driver information Communication	Display / Telematics																																					
Berlingo	Driver information Communication	Radio																																					
Berlingo	Driver information Communication	CD Player																																					
Berlingo	Driver information Communication	Instrument panel																																					
Berlingo	Driver information Communication	Switching module below steering wheel (COM 2000)																																					
Berlingo	Airbags	Airbags																																					
Berlingo	VisibilityLighting	Switching module below steering wheel (COM 2000)																																					
Berlingo	VisibilityLighting	Rain/sunlight sensor																																					
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P																																				
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																				
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																				
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																				
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P																																				
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801																																				
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2																																				
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																				
Berlingo	Active Safety	ESP BOSCH 5.7																																					
Berlingo	Active Safety	ABS BOSCH 8																																					
Berlingo	Active Safety	ESP BOSCH 8																																					
Berlingo	Active Safety	ABS 8.1																																					
Berlingo	Active Safety	ESP 8.1																																					

Vehicle	System 1	System 2	System 3	Replacement Of The Particle Emission Filter	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Replacement of the additive tank	Replacement of the additive pump	Reset to zero of the counter for the number of restarts	Brake cable replacement	Electric parking brake replacement	Calibration of the steering wheel angle sensor	Longitudinal acceleration sensor calibration	Replacement of the brake pads	Replacement of the brake pads	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB functior	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HW DV6BTED4 - 75 CV																																			
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HX DV6AUTED4 - 90 CV	V																																		
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HX-DV6ATED4 - 90 CV	V																																		
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HZ-DV6TED4 FAP - 110 CV	V																																		
Berlingo II	Injection(6th to 8th digit of VIN)	EDC17C10 BR2	9HN-DV6ETED	V																						V	V	V	V	V	V	V	V	V	V	V		
Berlingo II	Anti-lock brake system	ABS 8																																				
Berlingo II	Anti-lock brake system	ESP8.1_BOSCH													V																							
Berlingo II	Anti-lock brake system	ABS 81													V																							
Berlingo II	Airbag	Airbag																																				
Berlingo II	Power steering electric pump unit	Power steering electric pump unit																																				
Berlingo II	Instrument panel	Instrument panel																																				
Berlingo II	Radio	RD4																																				
Berlingo II	Radio	RD45																																				
Berlingo II	Rain sensor Brightness	Rain sensor / Brightness																																				
Berlingo II	Trailer relay unit	Trailer relay unit																																				
Berlingo II	Engine relay unit	Engine relay unit																																				
Berlingo II	Multiplexed additive pump	Multiplexed additive pump								V	V																											
Berlingo II	Multifunction display	Multifunction display																																				
Berlingo II	BSI	BSI																																				
Berlingo II	Switch module under the steering wheel	Switch module under the steering wheel																																				
Berlingo II	Switch module under the steering wheel	Switch module under the steering wheel																																				
NEMO	Engine(6th to 8th digit of VIN) Gearbox	EDC16C34																																				
NEMO	Engine(6th to 8th digit of VIN) Gearbox	HDI_8DF3																																				
NEMO	Engine(6th to 8th digit of VIN) Gearbox	BMF PUMA	BMF HDI 4C																																			
NEMO	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52_UDS 3.0 HDI 180CV E5		V																																		
NEMO	Engine(6th to 8th digit of VIN) Gearbox	SID208		V																																		
NEMO	ABSESP	ESP 90_F													V																							
NEMO	ABSESP	ESP 81													V	V																						
NEMO	ABSESP	ABS 81																																				
NEMO	Built-In system interface	Built-In system interface																																				
NEMO	Built-In system interface	Built-In system interface																																				
NEMO	Built-In system interface	Built-In system interface																																				
NEMO	Airbag	Airbag																																				
NEMO	LDWS	LDWS																																				
NEMO	Instrument	Instrument																																				
NEMO	Parking control	Parking control																																				

Vehicle	System 1	System 2	System 3	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Air Bleeding	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	Filling Of The Diesel Additive Adding Reservoir	Initialisation Of The 4 Diesel Injectors	Initialisation Of Diesel Injector 1	Initialisation Of Diesel Injector 2	Initialisation Of Diesel Injector 3	Initialisation Of Diesel Injector 4	Air Flow Sensor Replacement	Replacement Of The Differential Pressure Sensor	Change Of Engine Block Without The Flowmeter	Change Of Engine Block With The Flowmeter	Replacement Of The Ancillary Drive Belt	Checking The Immobiliser Code In The ECU	Oil Parameter Reinitialisation
C1	Engine ECU	Petrol engine	ME795																																			
C1	Gearbox ECU	MMT																																				
C1	Airbag	Airbag																																				
C1	ABS or ESP	ABS or ESP																																				
C1	Coded anti-start	ADC																																				
C1	Power steering	DAE																																				
C1(B4)	Engine ECU	ME17_9_52																																				
C1(B4)	ABS	RBV																																				
C1(B4)	EPS	EPS_T																																				
C1(B4)	Instrument panel	MET																																				
C1(B4)	Immobilizer	Immobilizer																																				
C2	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LPC																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	TU1A J34P																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	TU3A J34P																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745																																			
C2	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM2																																			
C2	Injection	Diesel (6th to 8th digit of VIN)	9HZ(FAP) BOSCH EDC16C34 DV6TED4																																			
C2	Injection	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C34 DV4TD																																			
C2	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID806																																			
C2	Gearbox ECU	Gearbox ECU																																				
C2	Airbag	Airbag																																				
C2	Anti-lock brake system	ABS MK 70																																				
C2	Anti-lock brake system	ABS MK70.1																																				
C2	Anti-lock brake system	ESP MK60																																				
C2	Anti-lock brake system	ESP MK60-O																																				
C2	BSI	BSI																																				
C2	Instrument panel	Instrument panel																																				
C2	Radio	Radio																																				
C2	CD player	CD player																																				
C2	Parking aid	Parking aid																																				
C2	Air conditioning	Air conditioning																																				
C2	Switch module under the steering wheel	Switch module under the steering wheel																																				
C2	Rain sensor Brightness	Rain sensor / Brightness																																				

Vehicle	System 1	System 2	System 3	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Air Bleeding	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	Filling Of The Diesel Additive Adding Reservoir	Initialisation Of The 4 Diesel Injectors	Initialisation Of Diesel Injector 1	Initialisation Of Diesel Injector 2	Initialisation Of Diesel Injector 3	Initialisation Of Diesel Injector 4	Air Flow Sensor Replacement	Replacement Of The Differential Pressure Sensor	Change Of Engine Block Without The Flowmeter	Change Of Engine Block With The Flowmeter	Replacement Of The Ancillary Drive Belt	Checking The Immobiliser Code In The ECU	Oil Parameter Reinitialisation
C2	Multifunction screen	Multifunction screen																																				
C2	Electric power steering ECU	Electric power steering ECU																																				
C3	Injection	Petrol (6th to 8th digit of VIN)	HFX MM48P																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME744																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME744																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV BOSCH ME744																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM1																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM2																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV BOSCH ME749																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 5FS																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 8FR																																			
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 8FP																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 CV6ATED4																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C34 DV4TD																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX BOSCH EDC16C34 DV4TD																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX SIEMENS SID802																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX SIEMENS SID804																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID804																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID806																																			
C3	Injection	Diesel (6th to 8th digit of VIN)	8HY DELPHI C6																																			
C3	Gearbox ECU	Auto gearbox BVA_AL4																																				
C3	Gearbox ECU	Controlled manual gearbox ECU																																				
C3	Airbag	Airbag																																				
C3	Anti-lock brake system	ABS MK60																																				
C3	Anti-lock brake system	ABS MK70																																				
C3	Anti-lock brake system	ESP																																				
C3	BSI	BSI																																				
C3	Instrument panel	Instrument panel																																				
C3	Radio	Radio																																				
C3	CD player	CD player																																				
C3	Parking aid	Parking aid																																				

Vehicle	System 1	System 2	System 3	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Air Bleeding	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	Filling Of The Diesel Additive Adding Reservoir	Initialisation Of The 4 Diesel Injectors	Initialisation Of Diesel Injector 1	Initialisation Of Diesel Injector 2	Initialisation Of Diesel Injector 3	Initialisation Of Diesel Injector 4	Air Flow Sensor Replacement	Replacement Of The Differential Pressure Sensor	Change Of Engine Block Without The Flowmeter	Change Of Engine Block With The Flowmeter	Replacement Of The Ancillary Drive Belt	Checking The Immobiliser Code In The ECU	Oil Parameter Reinitialisation
C3	Air conditioning	Air conditioning																																				
C3	Navigation	Navigation																																				
C3	Alarm	Alarm																																				
C3	Switch module under the steering wheel	Switch module under the steering wheel																																				
C3	Diesel additive function	Diesel additive function																																				
C3	Rain sensor Brightness	Rain sensor / Brightness																																				
C3	Driving school mode	Driving school mode																																				
C3	Multifunction display	Multifunction display																																				
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FT MED17.4																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FX MED17.4																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	6FY MM6LPB																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	MM6KP Bio Flex																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 23A																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 HMU																																			
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 HMZ																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR DELPHI DCM3.4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHF DELPHI DCM3.4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C34 DV6TED4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C34 DV6TED4																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	Engine type 42 : EB2DTS engine with 5-speed manual gearbox																																			
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	Engine type 44 : EB2DTS engine with 6-speed manual gearbox																																			

Vehicle	System 1	System 2	System 3	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Air Bleeding	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	Filling Of The Diesel Additive Adding Reservoir	Initialisation Of The 4 Diesel Injectors	Initialisation Of Diesel Injector 1	Initialisation Of Diesel Injector 2	Initialisation Of Diesel Injector 3	Initialisation Of Diesel Injector 4	Air Flow Sensor Replacement	Replacement Of The Differential Pressure Sensor	Change Of Engine Block Without The Flowmeter	Change Of Engine Block With The Flowmeter	Replacement Of The Ancillary Drive Belt	Checking The Immobiliser Code In The ECU	Oil Parameter Reinitialisation
C3 PLURIEL	Gearbox ECU	BVA_AL4_AT8																																				
C3 PLURIEL	Gearbox ECU	Controlled manual gearbox (BVMP)																																				
C3 PLURIEL	BSI	BSI																																				
C3 PLURIEL	Airbag	Airbag																																				
C3 PLURIEL	ABS or ESP	ABS_MK70.1																																				
C3 PLURIEL	ABS or ESP	ESP MK60-O																																				
C3 PLURIEL	Instrument panel	Instrument panel																																				
C3 PLURIEL	Radio	Radio																																				
C3 PLURIEL	Multifunction display	Multifunction display																																				
C3 PLURIEL	Power steering electric pump unit	Power steering electric pump unit																																				
C3 PLURIEL	Switch module at the steering wheel	Switch module at the steering wheel																																				
C3 PLURIEL	Sun roof	Sun roof																																				
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																			
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FS MEV17.4																																			
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FP MEV17.4																																			
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FS MEV17.4.2																																			
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FP MEV17.4.2																																			
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FR MED17.4																																			
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV																																			
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4- 90CV																																			
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HR HDI SID807																																			
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	EDC17C10 BR2																																			
C3 PICASSO	Gearbox ECU	BVA_AT8																																				
C3 PICASSO	Gearbox ECU	CFC300P																																				
C3 PICASSO	Gearbox ECU	BVA AM6 Euro5																																				
C3 PICASSO	BSI	BSI																																				
C3 PICASSO	Airbag	Airbag																																				
C3 PICASSO	ABS	ESP_MK60																																				
C3 PICASSO	ABS	ABS MK 70.2																																				
C3 PICASSO	Instrument panel	Instrument panel																																				
C3 PICASSO	Parking aid	Parking aid																																				
C3 PICASSO	Air conditioning	Air conditioning																																				
C3 PICASSO	Switch module under the steering wheel	Switch module under the steering wheel																																				
C3 PICASSO	Multifunction display	Multifunction display																																				
C3 PICASSO	Multiplexed additive pump	POMPE_MUX_MGI																																				
C3 PICASSO	Electric power steering	DAE																																				

Vehicle	System 1	System 2	System 3	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Air Bleeding	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	Filling Of The Diesel Additive Adding Reservoir	Initialisation Of The 4 Diesel Injectors	Initialisation Of Diesel Injector 1	Initialisation Of Diesel Injector 2	Initialisation Of Diesel Injector 3	Initialisation Of Diesel Injector 4	Air Flow Sensor Replacement	Replacement Of The Differential Pressure Sensor	Change Of Engine Block Without The Flowmeter	Change Of Engine Block With The Flowmeter	Replacement Of The Ancillary Drive Belt	Checking The Immobiliser Code In The ECU	Oil Parameter Reinitialisation
C3 PICASSO	Battery charge status unit	Battery charge status unit																																				
C3 PICASSO	Engine relay unit	Engine relay unit																																				
C3 PICASSO	Trailer relay unit	Trailer relay unit																																				
C3 PICASSO	Radio	Radio																																				
C3 PICASSO	Driver's door module	Driver's door module																																				
C3 PICASSO	Rain sensor	Rain sensor																																				
C3 PICASSO	Central voltage retention device	Central voltage retention device																																				
C4	Injection	Petrol (6th to 8th digit of VIN)	5FT MED17.4																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	5FX MED17.4																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	6FY MM6LPB																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	MM6KP Bio Flex																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 23A																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 HMU																																			
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 HMZ																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR DELPHI DCM3.4																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	RHF DELPHI DCM3.4																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C34 DV6TED4																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C34 DV6TED4																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	Engine type 42 : EB2DTS engine with 5-speed manual gearbox																																			
C4	Injection	Diesel (6th to 8th digit of VIN)	Engine type 44 : EB2DTS engine with 6-speed manual gearbox																																			
C4	Gearbox ECU	Auto gearbox AL4																																				

Vehicle	System 1	System 2	System 3	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Air Bleeding	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	Filling Of The Diesel Additive Adding Reservoir	Initialisation Of The 4 Diesel Injectors	Initialisation Of Diesel Injector 1	Initialisation Of Diesel Injector 2	Initialisation Of Diesel Injector 3	Initialisation Of Diesel Injector 4	Air Flow Sensor Replacement	Replacement Of The Differential Pressure Sensor	Change Of Engine Block Without The Flowmeter	Change Of Engine Block With The Flowmeter	Replacement Of The Ancillary Drive Belt	Checking The Immobiliser Code In The ECU	Oil Parameter Reinitialisation
C4	Gearbox ECU	Auto gearbox AL4																																				
C4	Gearbox ECU	Auto gearbox AM6																																				
C4	Gearbox ECU	CFC300P																																				
C4	Gearbox ECU	BVA AM6 Euro5																																				
C4	BSI	BSI																																				
C4	Airbag	Airbag																																				
C4	ABS or ESP	ABS 8_Bosch																																				
C4	ABS or ESP	ESP 8_1																																				
C4	ECU at the top of the steering column	ECU at the top of the steering column																																				
C4	Instrument panel	Instrument panel																																				
C4	Radio	Radio																																				
C4	CD player	CD player																																				
C4	Parking aid	Parking aid																																				
C4	Air conditioning	Air conditioning																																				
C4	Multifunction display	Multifunction display																																				
C4	Power steering electric pump unit	Power steering electric pump unit																																				
C4	Engine relay unit	Engine relay unit																																				
C4	Trailer relay unit	Trailer relay unit																																				
C4	Remote instrument panel unit	Remote instrument panel unit																																				
C4	Passenger door electronics	Passenger door electronics																																				
C4	Driver's door electronics	Driver's door electronics																																				
C4 II	Engine(6th to 8th digit of VIN)	MED17_4_2	5FV MED17_4_2 EURO5																																			
C4 II	Engine(6th to 8th digit of VIN)	EDC17C10 BR2																																				
C4 II	Engine(6th to 8th digit of VIN)	9HR HDI SID807																																				
C4 II	Gearbox ECU	BVA_AT8																																				
C4 II	Gearbox ECU	CFC300P																																				
C4 II	Gearbox ECU	BVA AM6 Euro5																																				
C4 II	Airbag	RBG_UDS																																				
C4 II	ABS Electronic stability program	ESP 8.1																																				
C4 II	BSI	BSI																																				
C4 II	Power steering electric pump unit	GET																																				
C4 II	Battery charge status unit	Battery charge status unit																																				
C4 II	Engine relay unit	Engine relay unit																																				
C4 II	Display	Display																																				
C4 II	Driver's door module	Driver's door module																																				
C4 II	Electric secondary brake	Electric secondary brake																																				

Vehicle	System 1	System 2	System 3	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Air Bleeding	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	Filling Of The Diesel Additive Adding Reservoir	Initialisation Of The 4 Diesel Injectors	Initialisation Of Diesel Injector 1	Initialisation Of Diesel Injector 2	Initialisation Of Diesel Injector 3	Initialisation Of Diesel Injector 4	Air Flow Sensor Replacement	Replacement Of The Differential Pressure Sensor	Change Of Engine Block Without The Flowmeter	Change Of Engine Block With The Flowmeter	Replacement Of The Ancillary Drive Belt	Checking The Immobiliser Code In The ECU	Oil Parameter Reinitialisation
C4 II	Trailer relay unit	Trailer relay unit																																				
C4 II	Seat belts not fastened LED unit	Seat belts not fastened LED unit																																				
C4 II	Multiplexed control panel	Multiplexed control panel																																				
C4 II	Controls on the steering wheel	Controls on the steering wheel																																				
C4 II	Supply protection and management unit	Supply protection and management unit																																				
C4 II	Windscreen wiper	Windscreen wiper																																				
C4 II	Switch module at the steering wheel	Switch module at the steering wheel																																				
C4 II	Heatingventilation	Heating/ventilation																																				
C4 II	Instrument panel	Instrument panel																																				
C4 II	Radio or radiotelephone	Radio or radiotelephone																																				
C4 II	Passenger door electronics	Passenger door electronics																																				
C4 II	Rain and brightness sensor	Rain and brightness sensor																																				
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FT MED17.4																																			
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FX MED17.4																																			
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																			
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB																																			
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	6FY MM6LPB																																			
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FV MED17_4_2																																			
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HZ(FAP) BOSCH EDC16C34 DV6TED4																																			
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A																																			
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	RHJ SIEMENS SID803A																																			
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HR HDI SID807																																			
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HL - DV6CTED - 111 CV HDI_SID807_BR2																																			
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HR - DV6CTED - 111 CV HDI_SID807_BR2																																			
C4 PICASSO	Gearbox ECU	Auto gearbox AL4																																				
C4 PICASSO	Gearbox ECU	Auto gearbox AL4																																				
C4 PICASSO	Gearbox ECU	Auto gearbox AM6																																				
C4 PICASSO	Gearbox ECU	CFC300P																																				
C4 PICASSO	Gearbox ECU	BVA AM6 Euro5																																				
C4 PICASSO	Driver and passenger airbags	Driver and passenger airbags																																				
C4 PICASSO	ABS Electronic stability program	ESP 8.1																																				
C4 PICASSO	ABS Electronic stability program	90 ESP																																				
C4 PICASSO	BSI	BSI																																				
C4 PICASSO	Power steering electric pump unit(GEP)	Power steering electric pump unit(GEP)																																				
C4 PICASSO	Power steering electric pump unit(GEP)	Power steering electric pump unit(GEP)																																				
C4 PICASSO	Battery charge status unit	Battery charge status unit																																				

Vehicle	System 1	System 2	System 3	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Air Bleeding	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	Filling Of The Diesel Additive Adding Reservoir	Initialisation Of The 4 Diesel Injectors	Initialisation Of Diesel Injector 1	Initialisation Of Diesel Injector 2	Initialisation Of Diesel Injector 3	Initialisation Of Diesel Injector 4	Air Flow Sensor Replacement	Replacement Of The Differential Pressure Sensor	Change Of Engine Block Without The Flowmeter	Change Of Engine Block With The Flowmeter	Replacement Of The Ancillary Drive Belt	Checking The Immobiliser Code In The ECU	Oil Parameter Reinitialisation
C4 PICASSO	Electric secondary brake	Electric secondary brake																																				
C4 PICASSO	Engine relay unit	Engine relay unit																																				
C4 PICASSO	Trailer relay unit	Trailer relay unit																																				
C4 PICASSO	Windscreen wiper	Windscreen wiper																																				
C4 PICASSO	ECU at the top of the steering column	ECU at the top of the steering column																																				
C4 PICASSO	Heatingventilation	Heating/ventilation																																				
C4 PICASSO	Instrument panel	Instrument panel																																				
C4 PICASSO	Radio or radiotelephone	Radio or radiotelephone																																				
C4 PICASSO	Passenger door electronics	Passenger door electronics																																				
C4 PICASSO	Passenger door electronics	Passenger door electronics																																				
C4 PICASSO	Driver's door electronics	Driver's door electronics																																				
C4 PICASSO	Driver's door electronics	Driver's door electronics																																				
C4 PICASSO	Rain and brightness sensor	Rain and brightness sensor																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	DCM3.5_BR2		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																		
C4 Cactus	Engine(6th to 8th digit of VIN)	SID807																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	MED17_4_4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																				
C4 Cactus	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																				
C4 Cactus	Gearbox ECU	AM6 Euro5 automatic gearbox																																				
C4 Cactus	Gearbox ECU	AT6 Euro5 automatic gearbox																																				
C4 Cactus	Gearbox ECU	CFC300P gearbox																																				
C4 Cactus	Gearbox ECU	AL4 automatic gearbox																																				
C4 Cactus	Gearbox ECU	BVA_AM6_AT6_UDS																																				
C4 Cactus	Multiplexed additive adding pump ECU	Multiplexed additive adding pump ECU																																				
C4 Cactus	ABS or ESP ECU	ESP 81																			V																	
C4 Cactus	ABS or ESP ECU	ESP MK 100																				V	V	V														

Vehicle	System 1	System 2	System 3	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Air Bleeding	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	Filling Of The Diesel Additive Adding Reservoir	Initialisation Of The 4 Diesel Injectors	Initialisation Of Diesel Injector 1	Initialisation Of Diesel Injector 2	Initialisation Of Diesel Injector 3	Initialisation Of Diesel Injector 4	Air Flow Sensor Replacement	Replacement Of The Differential Pressure Sensor	Change Of Engine Block Without The Flowmeter	Change Of Engine Block With The Flowmeter	Replacement Of The Ancillary Drive Belt	Checking The Immobiliser Code In The ECU	Oil Parameter Reinitialisation
C4 Cactus	ABS or ESP ECU	90 ESP																																				
C4 Cactus	Headlamp height adjuster directional headlamp	Headlamp height adjuster/ directional headlamp																																				
C4 Cactus	Built-In system interface	Built-In system interface																																				
C4 Cactus	Built-In system interface	Built-In system interface																																				
C4 Cactus	Power steering electric pump unit	GEP																																				
C4 Cactus	Power steering electric pump unit	DAE_BVH2																																				
C4 Cactus	Battery charge status unit	BECB_GEN2																																				
C4 Cactus	Electric secondary brake	FSE																																				
C4 Cactus	Engine relay unit	BSM																																				
C4 Cactus	Trailer relay unit	BSR																																				
C4 Cactus	Airbag ECU	RBG_UDS																																				
C4 Cactus	Airbag ECU	RBG_UDS																																				
C4 Cactus	Airbag ECU	SAC_AUTOLIV																																				
C4 Cactus	Instrument panel	COMBINE																																				
C4 Cactus	Instrument panel	COMBINE																																				
C4 Cactus	Rain-sunlight sensor	Rain and brightness sensor																																				
C4 Cactus	Rain-sunlight sensor	CDPL_UDS_HELLA																							V													
C4 Cactus	Switch module at the steering wheel	COM2008P																																				
C4 Cactus	Switch module at the steering wheel	HDC																																				
C4 Cactus	Bodywork conversion unit	BTC																																				
C4 Cactus	Parking aid	AAS																																				
C4 Cactus	Additional heating	CHAUFF_ADD																																				
C4 Cactus	Telematics unit	SMEG_PLUS																																				
C4 Cactus	Anti-theft alarm	ALARME																																				
C4 Cactus	Rear air conditioning table	TAB_CLIM_AR																																				
C4 Cactus	Rain and brightness sensor	PLUIE_LUMINOSITE																																				
C4 Cactus	Supply protection and management unit	BPGA2010																																				
C4 Cactus	Door control pad	PDPC_UDS																																				
C4 Cactus	Air conditioning	BCC																																				
C4 Cactus	Touch screen	Touch screen																																				
C4 Cactus	Seat belts not fastened LED unit	TNB_2010																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	MED17_4_2	5FV MED17_4_2 EURO5																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																				
C-ELYSEE	Engine(6th to 8th digit of VIN)	DCM3.5_BR2		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																		
C-ELYSEE	Engine(6th to 8th digit of VIN)	SID807																																				

Vehicle	System 1	System 2	System 3	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Air Bleeding	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	Filling Of The Diesel Additive Adding Reservoir	Initialisation Of The 4 Diesel Injectors	Initialisation Of Diesel Injector 1	Initialisation Of Diesel Injector 2	Initialisation Of Diesel Injector 3	Initialisation Of Diesel Injector 4	Air Flow Sensor Replacement	Replacement Of The Differential Pressure Sensor	Change Of Engine Block Without The Flowmeter	Change Of Engine Block With The Flowmeter	Replacement Of The Ancillary Drive Belt	Checking The Immobiliser Code In The ECU	Oil Parameter Reinitialisation
C-ELYSEE	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	MED17_4_4																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																			
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																			
C-ELYSEE	Gearbox ECU	BVA_AT8																																			
C-ELYSEE	Gearbox ECU	CFC300P																																			
C-ELYSEE	Gearbox ECU	BVA AM6 Euro5																																			
C-ELYSEE	Airbag	RBG_UDS																																			
C-ELYSEE	ABS_Electronic stability program	ESP 8.1																																			
C-ELYSEE	ABS_Electronic stability program	ABS 81																																			
C-ELYSEE	BSI	BSI2010																																			
C-ELYSEE	Power steering electric pump unit	GET																																			
C-ELYSEE	Battery charge status unit	Battery charge status unit																																			
C-ELYSEE	Electric secondary brake	Electric secondary brake																																			
C-ELYSEE	Trailer relay unit	Trailer relay unit																																			
C-ELYSEE	Windscreen wiper	Windscreen wiper																																			
C-ELYSEE	Switch module at the steering wheel	Switch module at the steering wheel																																			
C-ELYSEE	Heatingventilation	Heating/ventilation																																			
C-ELYSEE	Instrument panel	Instrument panel																																			
C-ELYSEE	Radio or radiotelephone	Radio or radiotelephone																																			
C-ELYSEE	Passenger door electronics	Passenger door electronics																																			
C-ELYSEE	Rain and brightness sensor	Rain and brightness sensor																																			
JUMPY	Injection(6th to 8th digit of VIN)	EDC16C3	9HU-DV6UTED4 - 90 CV																																		
JUMPY	Injection(6th to 8th digit of VIN)	DCM3.5_BR2	AHZ-DW10CD-128CV																							V	V	V	V	V	V	V	V	V	V	V	V
JUMPY	Anti-lock brake system	ABS 8.1																																			
JUMPY	Airbag	Airbag																																			
JUMPY	Trailer relay unit	Trailer relay unit																																			
JUMPY	Engine relay unit	Engine relay unit																																			
JUMPY	BSI	BSI																																			

Vehicle	System 1	System 2	System 3	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Air Bleeding	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	Filling Of The Diesel Additive Adding Reservoir	Initialisation Of The 4 Diesel Injectors	Initialisation Of Diesel Injector 1	Initialisation Of Diesel Injector 2	Initialisation Of Diesel Injector 3	Initialisation Of Diesel Injector 4	Air Flow Sensor Replacement	Replacement Of The Differential Pressure Sensor	Change Of Engine Block Without The Flowmeter	Change Of Engine Block With The Flowmeter	Replacement Of The Ancillary Drive Belt	Checking The Immobiliser Code In The ECU	Oil Parameter Reinitialisation
JUMPY	Switch module under the steering wheel	Switch module under the steering wheel																																				
JUMPY	Bodywork conversion unit	Bodywork conversion unit																																				
Jumper	Engine(6th to 8th digit of VIN) Gearbox	PUMA	PUMA 4HV																																			V
Jumper	Engine(6th to 8th digit of VIN) Gearbox	PUMA	PUMA 4HU(120 or 130)																																			V
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC16C39	EDC16C39 TUB																																			
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52	EDC17CP52 SOFIM EURO5																																			
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52_UDS 3.0 HDI 180CV E5	EDC17CP52_UDS 3.0 HDI 180CV E5																																			V
Jumper	Engine(6th to 8th digit of VIN) Gearbox	SID208	SID208																														V					V
Jumper	ABSESP	ESP90_F																																				
Jumper	Power steering	SSCU																																				
Jumper	Airbag	Airbag																																				
Jumper	Built-In system interface	Built-In system interface																																				
Jumper	Built-In system interface	Built-In system interface																																				
Berlingo	Driving assistance Comfort	Parking aid																																				
Berlingo	Built-In system interface	Built-In system interface																																				
Berlingo	Driver information Communication	Display / Telematics																																				
Berlingo	Driver information Communication	Radio																																				
Berlingo	Driver information Communication	CD Player																																				
Berlingo	Driver information Communication	Instrument panel																																				
Berlingo	Driver information Communication	Switching module below steering wheel (COM 2000)																																				
Berlingo	Airbags	Airbags																																				
Berlingo	VisibilityLighting	Switching module below steering wheel (COM 2000)																																				
Berlingo	VisibilityLighting	Rain/sunlight sensor																																				
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P																																			
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																			
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																			
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																			
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P																																			
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801																																			
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2																																			
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																			
Berlingo	Active Safety	ESP BOSCH 5.7																																				
Berlingo	Active Safety	ABS BOSCH 8																																				
Berlingo	Active Safety	ESP BOSCH 8																																				
Berlingo	Active Safety	ABS 8.1																																				
Berlingo	Active Safety	ESP 8.1																																				

Vehicle	System 1	System 2	System 3	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Air Bleeding	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	Filling Of The Diesel Additive Adding Reservoir	Initialisation Of The 4 Diesel Injectors	Initialisation Of Diesel Injector 1	Initialisation Of Diesel Injector 2	Initialisation Of Diesel Injector 3	Initialisation Of Diesel Injector 4	Air Flow Sensor Replacement	Replacement Of The Differential Pressure Sensor	Change Of Engine Block Without The Flowmeter	Change Of Engine Block With The Flowmeter	Replacement Of The Ancillary Drive Belt	Checking The Immobiliser Code In The ECU	Oil Parameter Reinitialisation
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HW DV6BTED4 - 75 CV																																			
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HX DV6AUTED4 - 90 CV																																			
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HX-DV6ATED4 - 90 CV																																			
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HZ-DV6TED4 FAP - 110 CV																																			
Berlingo II	Injection(6th to 8th digit of VIN)	EDC17C10 BR2	9HN-DV6ETED																																			
Berlingo II	Anti-lock brake system	ABS 8																																				
Berlingo II	Anti-lock brake system	ESP8.1_BOSCH																			V																	
Berlingo II	Anti-lock brake system	ABS 81																			V																	
Berlingo II	Airbag	Airbag																																				
Berlingo II	Power steering electric pump unit	Power steering electric pump unit																																				
Berlingo II	Instrument panel	Instrument panel																																				
Berlingo II	Radio	RD4																																				
Berlingo II	Radio	RD45																																				
Berlingo II	Rain sensor Brightness	Rain sensor / Brightness																																				
Berlingo II	Trailer relay unit	Trailer relay unit																																				
Berlingo II	Engine relay unit	Engine relay unit																																				
Berlingo II	Multiplexed additive pump	Multiplexed additive pump																																				
Berlingo II	Multifunction display	Multifunction display																																				
Berlingo II	BSI	BSI																																				
Berlingo II	Switch module under the steering wheel	Switch module under the steering wheel																																				
Berlingo II	Switch module under the steering wheel	Switch module under the steering wheel																																				
NEMO	Engine(6th to 8th digit of VIN) Gearbox	EDC16C34																																				
NEMO	Engine(6th to 8th digit of VIN) Gearbox	HDI_8DF3																																				
NEMO	Engine(6th to 8th digit of VIN) Gearbox	BMF PUMA	BMF HDI 4C																																			V
NEMO	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52_UDS 3.0 HDI 180CV E5																																				V
NEMO	Engine(6th to 8th digit of VIN) Gearbox	SID208																															V					V
NEMO	ABSESP	ESP 90_F																																				
NEMO	ABSESP	ESP 81																																				
NEMO	ABSESP	ABS 81																																				
NEMO	Built-In system interface	Built-In system interface																																				
NEMO	Built-In system interface	Built-In system interface																																				
NEMO	Built-In system interface	Built-In system interface																																				
NEMO	Airbag	Airbag																																				
NEMO	LDWS	LDWS																																				
NEMO	Instrument	Instrument																																				
NEMO	Parking control	Parking control																																				

Vehicle	System 1	System 2	System 3	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Programming of the Confidential Code of the BSI	Programming of keys	Configuration View Only	Auto Configuration	Forced Regeneration Of The Particulate Filter While Stationary	Forced regeneration of the Particulate filter while driving	Particulate Filter Replacement	Initialisation of the additive level when filling or replacing the additive reservoir	Longitudinal Acceleration Sensor Calibration	Configuration of the instrument panel	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset	Calibration of the longitudinal and lateral acceleration senso	Decalibration of the longitudinal and lateral acceleration sensor
C1	Engine ECU	Petrol engine	ME795																																
C1	Gearbox ECU	MMT																																	
C1	Airbag	Airbag																																	
C1	ABS or ESP	ABS or ESP																																	
C1	Coded anti-start	ADC																																	
C1	Power steering	DAE																																	
C1(B4)	Engine ECU	ME17_9_52																																	
C1(B4)	ABS	RBV																																	
C1(B4)	EPS	EPS_T																																	
C1(B4)	Instrument panel	MET																																	
C1(B4)	Immobilizer	Immobilizer																																	
C2	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LPC																																
C2	Injection	Petrol (6th to 8th digit of VIN)	TU1A J34P																																
C2	Injection	Petrol (6th to 8th digit of VIN)	TU3A J34P																																
C2	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745																																
C2	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745																																
C2	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745																																
C2	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745																																
C2	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM2																																
C2	Injection	Diesel (6th to 8th digit of VIN)	9HZ(FAP) BOSCH EDC16C34 DV6TED4																																
C2	Injection	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C34 DV4TD																																
C2	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID806																																
C2	Gearbox ECU	Gearbox ECU																																	
C2	Airbag	Airbag																																	
C2	Anti-lock brake system	ABS MK 70																																	
C2	Anti-lock brake system	ABS MK70.1																																	
C2	Anti-lock brake system	ESP MK60																																	
C2	Anti-lock brake system	ESP MK60-O																																	
C2	BSI	BSI																																	
C2	Instrument panel	Instrument panel																																	
C2	Radio	Radio																																	
C2	CD player	CD player																																	
C2	Parking aid	Parking aid																																	
C2	Air conditioning	Air conditioning																																	
C2	Switch module under the steering wheel	Switch module under the steering wheel																																	
C2	Rain sensor Brightness	Rain sensor / Brightness																																	

Vehicle	System 1	System 2	System 3	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Programming of the Confidential Code of the BSI	Programming of keys	Configuration View Only	Auto Configuration	Forced Regeneration Of Thte Particulate Filter While Stationary	Forced regeneration of the Particulate filter while driving	Particulate Filter Replacement	Initialisation of the additive level when filling or replacing the additive reservoir	Longitudinal Acceleration Sensor Calibration	Configuration of the instrument panel	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset	Calibration of the longitudinal and lateral acceleration senso	Decalibration of the longitudinal and lateral acceleration sensor
C2	Multifunction screen	Multifunction screen																																	
C2	Electric power steering ECU	Electric power steering ECU																																	
C3	Injection	Petrol (6th to 8th digit of VIN)	HFX MM48P																																
C3	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																
C3	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME744																																
C3	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME744																																
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV BOSCH ME744																																
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM1																																
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV SAGEM S2000PM2																																
C3	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749																																
C3	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749																																
C3	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME749																																
C3	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME749																																
C3	Injection	Petrol (6th to 8th digit of VIN)	KFV BOSCH ME749																																
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 5FS																																
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 8FR																																
C3	Injection	Petrol (6th to 8th digit of VIN)	MEV17_4_EURO5 8FP																																
C3	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 CV6ATED4																																
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C34 DV4TD																																
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX BOSCH EDC16C34 DV4TD																																
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX SIEMENS SID802																																
C3	Injection	Diesel (6th to 8th digit of VIN)	8HX SIEMENS SID804																																
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID804																																
C3	Injection	Diesel (6th to 8th digit of VIN)	8HZ SIEMENS SID806																																
C3	Injection	Diesel (6th to 8th digit of VIN)	8HY DELPHI C6																																
C3	Gearbox ECU	Auto gearbox BVA_AL4																																	
C3	Gearbox ECU	Controlled manual gearbox ECU																																	
C3	Airbag	Airbag																																	
C3	Anti-lock brake system	ABS MK60																																	
C3	Anti-lock brake system	ABS MK70																																	
C3	Anti-lock brake system	ESP																																	
C3	BSI	BSI																																	
C3	Instrument panel	Instrument panel																																	
C3	Radio	Radio																																	
C3	CD player	CD player																																	
C3	Parking aid	Parking aid																																	

Vehicle	System 1	System 2	System 3	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Programming of the Confidential Code of the BSI	Programming of keys	Configuration View Only	Auto Configuration	Forced Regeneration Of Thre Particulate Filter While Stationary	Forced regeneration of the Particulate filter while driving	Particulate Filter Replacement	Initialisation of the additive level when filling or replacing the additive reservoir	Longitudinal Acceleration Sensor Calibration	Configuration of the instrument panel	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset	Calibration of the longitudinal and lateral acceleration senso	Decalibration of the longitudinal and lateral acceleration sensor
C3	Air conditioning	Air conditioning																																	
C3	Navigation	Navigation																																	
C3	Alarm	Alarm																																	
C3	Switch module under the steering wheel	Switch module under the steering wheel																																	
C3	Diesel additive function	Diesel additive function																																	
C3	Rain sensor Brightness	Rain sensor / Brightness																																	
C3	Driving school mode	Driving school mode																																	
C3	Multifunction display	Multifunction display																																	
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FT MED17.4																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FX MED17.4																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	6FY MM6LPB																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	MM6KP Bio Flex																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 23A																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 HMU																																
C3 PLURIEL	Injection	Petrol (6th to 8th digit of VIN)	V46 HMZ																																
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR DELPHI DCM3.4																																
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHF DELPHI DCM3.4																																
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C34 DV6TED4																																
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4																																
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4																																
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C34 DV6TED4																																
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A																																
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803																																
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	Engine type 42 : EB2DTS engine with 5-speed manual gearbox																																
C3 PLURIEL	Injection	Diesel (6th to 8th digit of VIN)	Engine type 44 : EB2DTS engine with 6-speed manual gearbox																																

Vehicle	System 1	System 2	System 3	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Programming of the Confidential Code of the BSI	Programming of keys	Configuration View Only	Auto Configuration	Forced Regeneration Of Thte Particulate Filter While Stationary	Forced regeneration of the Particulate filter while driving	Particulate Filter Replacement	Initialisation of the additive level when filling or replacing the additive reservoir	Longitudinal Acceleration Sensor Calibration	Configuration of the instrument panel	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset	Calibration of the longitudinal and lateral acceleration senso	Decalibration of the longitudinal and lateral acceleration sensor
C3 PLURIEL	Gearbox ECU	BVA_AL4_AT8																																	
C3 PLURIEL	Gearbox ECU	Controlled manual gearbox (BVMP)																																	
C3 PLURIEL	BSI	BSI																																	
C3 PLURIEL	Airbag	Airbag																																	
C3 PLURIEL	ABS or ESP	ABS_MK70.1																																	
C3 PLURIEL	ABS or ESP	ESP MK60-O																																	
C3 PLURIEL	Instrument panel	Instrument panel																																	
C3 PLURIEL	Radio	Radio																																	
C3 PLURIEL	Multifunction display	Multifunction display																																	
C3 PLURIEL	Power steering electric pump unit	Power steering electric pump unit																																	
C3 PLURIEL	Switch module at the steering wheel	Switch module at the steering wheel																																	
C3 PLURIEL	Sun roof	Sun roof																																	
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FS MEV17.4																																
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FP MEV17.4																																
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FS MEV17.4.2																																
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	8FP MEV17.4.2																																
C3 PICASSO	Injection	Petrol (6th to 8th digit of VIN)	5FR MED17.4																																
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV																																
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4- 90CV																																
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	9HR HDI SID807																																
C3 PICASSO	Injection	Diesel (6th to 8th digit of VIN)	EDC17C10 BR2																																
C3 PICASSO	Gearbox ECU	BVA_AT8																																	
C3 PICASSO	Gearbox ECU	CFC300P																																	
C3 PICASSO	Gearbox ECU	BVA AM6 Euro5																																	
C3 PICASSO	BSI	BSI																																	
C3 PICASSO	Airbag	Airbag																																	
C3 PICASSO	ABS	ESP_MK60																																	
C3 PICASSO	ABS	ABS MK 70.2																																	
C3 PICASSO	Instrument panel	Instrument panel																																	
C3 PICASSO	Parking aid	Parking aid																																	
C3 PICASSO	Air conditioning	Air conditioning																																	
C3 PICASSO	Switch module under the steering wheel	Switch module under the steering wheel																																	
C3 PICASSO	Multifunction display	Multifunction display																																	
C3 PICASSO	Multiplexed additive pump	POMPE_MUX_MGI																																	
C3 PICASSO	Electric power steering	DAE																																	

Vehicle	System 1	System 2	System 3	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Programming of the Confidential Code of the BSI	Programming of keys	Configuration View Only	Auto Configuration	Forced Regeneration Of The Particulate Filter While Stationary	Forced regeneration of the Particulate filter while driving	Particulate Filter Replacement	Initialisation of the additive level when filling or replacing the additive reservoir	Longitudinal Acceleration Sensor Calibration	Configuration of the instrument panel	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset	Calibration of the longitudinal and lateral acceleration senso	Decalibration of the longitudinal and lateral acceleration sensor
C3 PICASSO	Battery charge status unit	Battery charge status unit																																	
C3 PICASSO	Engine relay unit	Engine relay unit																																	
C3 PICASSO	Trailer relay unit	Trailer relay unit																																	
C3 PICASSO	Radio	Radio																																	
C3 PICASSO	Driver's door module	Driver's door module																																	
C3 PICASSO	Rain sensor	Rain sensor																																	
C3 PICASSO	Central voltage retention device	Central voltage retention device																																	
C4	Injection	Petrol (6th to 8th digit of VIN)	5FT MED17.4																																
C4	Injection	Petrol (6th to 8th digit of VIN)	5FX MED17.4																																
C4	Injection	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																
C4	Injection	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																
C4	Injection	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																
C4	Injection	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																
C4	Injection	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB																																
C4	Injection	Petrol (6th to 8th digit of VIN)	6FY MM6LPB																																
C4	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME745																																
C4	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME745																																
C4	Injection	Petrol (6th to 8th digit of VIN)	NFS BOSCH ME745																																
C4	Injection	Petrol (6th to 8th digit of VIN)	NFR BOSCH ME745																																
C4	Injection	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME749																																
C4	Injection	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749																																
C4	Injection	Petrol (6th to 8th digit of VIN)	MM6KP Bio Flex																																
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 23A																																
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 HMU																																
C4	Injection	Petrol (6th to 8th digit of VIN)	V46 HMZ																																
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR DELPHI DCM3.4																																
C4	Injection	Diesel (6th to 8th digit of VIN)	RHF DELPHI DCM3.4																																
C4	Injection	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C34 DV6TED4																																
C4	Injection	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C34 DV6ATED4																																
C4	Injection	Diesel (6th to 8th digit of VIN)	9HZ (FAP) BOSCH EDC16C34 DV6TED4																																
C4	Injection	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C34 DV6TED4																																
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A																																
C4	Injection	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803																																
C4	Injection	Diesel (6th to 8th digit of VIN)	Engine type 42 : EB2DTS engine with 5-speed manual gearbox																																
C4	Injection	Diesel (6th to 8th digit of VIN)	Engine type 44 : EB2DTS engine with 6-speed manual gearbox																																
C4	Gearbox ECU	Auto gearbox AL4																																	

Vehicle	System 1	System 2	System 3	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Programming of the Confidential Code of the BSI	Programming of keys	Configuration View Only	Auto Configuration	Forced Regeneration Of Thhe Particulate Filter While Stationary	Forced regeneration of the Particulate filter while driving	Particulate Filter Replacement	Initialisation of the additive level when filling or replacing the additive reservoir	Longitudinal Acceleration Sensor Calibration	Configuration of the instrument panel	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset	Calibration of the longitudinal and lateral acceleration senso	Decalibration of the longitudinal and lateral acceleration sensor
C4	Gearbox ECU	Auto gearbox AL4																																	
C4	Gearbox ECU	Auto gearbox AM6																																	
C4	Gearbox ECU	CFC300P																																	
C4	Gearbox ECU	BVA AM6 Euro5																																	
C4	BSI	BSI																																	
C4	Airbag	Airbag																																	
C4	ABS or ESP	ABS 8_Bosch																																	
C4	ABS or ESP	ESP 8_1																																	
C4	ECU at the top of the steering column	ECU at the top of the steering column																																	
C4	Instrument panel	Instrument panel																																	
C4	Radio	Radio																																	
C4	CD player	CD player																																	
C4	Parking aid	Parking aid																																	
C4	Air conditioning	Air conditioning																																	
C4	Multifunction display	Multifunction display																																	
C4	Power steering electric pump unit	Power steering electric pump unit																																	
C4	Engine relay unit	Engine relay unit																																	
C4	Trailer relay unit	Trailer relay unit																																	
C4	Remote instrument panel unit	Remote instrument panel unit																																	
C4	Passenger door electronics	Passenger door electronics																																	
C4	Driver's door electronics	Driver's door electronics																																	
C4 II	Engine(6th to 8th digit of VIN)	MED17_4_2	5FV MED17_4_2 EURO5																																
C4 II	Engine(6th to 8th digit of VIN)	EDC17C10 BR2																																	
C4 II	Engine(6th to 8th digit of VIN)	9HR HDI SID807																																	
C4 II	Gearbox ECU	BVA_AT8																																	
C4 II	Gearbox ECU	CFC300P																																	
C4 II	Gearbox ECU	BVA AM6 Euro5																																	
C4 II	Airbag	RBG_UDS																																	
C4 II	ABS Electronic stability program	ESP 8.1																																	
C4 II	BSI	BSI																																	
C4 II	Power steering electric pump unit	GET																																	
C4 II	Battery charge status unit	Battery charge status unit																																	
C4 II	Engine relay unit	Engine relay unit																																	
C4 II	Display	Display																																	
C4 II	Driver's door module	Driver's door module																																	
C4 II	Electric secondary brake	Electric secondary brake																																	

Vehicle	System 1	System 2	System 3	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Programming of the Confidential Code of the BSI	Programming of keys	Configuration View Only	Auto Configuration	Forced Regeneration Of Thre Particulate Filter While Stationary	Forced regeneration of the Particulate filter while driving	Particulate Filter Replacement	Initialisation of the additive level when filling or replacing the additive reservoir	Longitudinal Acceleration Sensor Calibration	Configuration of the instrument panel	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset	Calibration of the longitudinal and lateral acceleration senso	Decalibration of the longitudinal and lateral acceleration sensor
C4 II	Trailer relay unit	Trailer relay unit																																	
C4 II	Seat belts not fastened LED unit	Seat belts not fastened LED unit																																	
C4 II	Multiplexed control panel	Multiplexed control panel																																	
C4 II	Controls on the steering wheel	Controls on the steering wheel																																	
C4 II	Supply protection and management unit	Supply protection and management unit																																	
C4 II	Windscreen wiper	Windscreen wiper																																	
C4 II	Switch module at the steering wheel	Switch module at the steering wheel																																	
C4 II	Heatingventilation	Heating/ventilation																																	
C4 II	Instrument panel	Instrument panel																																	
C4 II	Radio or radiotelephone	Radio or radiotelephone																																	
C4 II	Passenger door electronics	Passenger door electronics																																	
C4 II	Rain and brightness sensor	Rain and brightness sensor																																	
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FT MED17.4																																
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FX MED17.4																																
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FW MEV17.4																																
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	RFJ MM6LPB																																
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	6FY MM6LPB																																
C4 PICASSO	Injection Ignition	Petrol (6th to 8th digit of VIN)	5FV MED17_4_2																																
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HZ(FAP) BOSCH EDC16C34 DV6TED4																																
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID803A																																
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	RHJ SIEMENS SID803A																																
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HR HDI SID807																																
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HL - DV6CTED - 111 CV HDI_SID807_BR2																																
C4 PICASSO	Injection Ignition	Diesel (6th to 8th digit of VIN)	9HR - DV6CTED - 111 CV HDI_SID807_BR2																																
C4 PICASSO	Gearbox ECU	Auto gearbox AL4																																	
C4 PICASSO	Gearbox ECU	Auto gearbox AL4																																	
C4 PICASSO	Gearbox ECU	Auto gearbox AM6																																	
C4 PICASSO	Gearbox ECU	CFC300P																																	
C4 PICASSO	Gearbox ECU	BVA AM6 Euro5																																	
C4 PICASSO	Driver and passenger airbags	Driver and passenger airbags																																	
C4 PICASSO	ABS Electronic stability program	ESP 8.1																																	
C4 PICASSO	ABS Electronic stability program	90 ESP																																	
C4 PICASSO	BSI	BSI																																	
C4 PICASSO	Power steering electric pump unit(GEP)	Power steering electric pump unit(GEP)																																	
C4 PICASSO	Power steering electric pump unit(GEP)	Power steering electric pump unit(GEP)																																	
C4 PICASSO	Battery charge status unit	Battery charge status unit																																	

Vehicle	System 1	System 2	System 3	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Programming of the Confidential Code of the BSI	Programming of keys	Configuration View Only	Auto Configuration	Forced Regeneration Of Thhe Particulate Filter While Stationary	Forced regeneration of the Particulate filter while driving	Particulate Filter Replacement	Initialisation of the additive level when filling or replacing the additive reservoir	Longitudinal Acceleration Sensor Calibration	Configuration of the instrument panel	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset	Calibration of the longitudinal and lateral acceleration senso	Decalibration of the longitudinal and lateral acceleration sensor
C4 PICASSO	Electric secondary brake	Electric secondary brake																																	
C4 PICASSO	Engine relay unit	Engine relay unit																																	
C4 PICASSO	Trailer relay unit	Trailer relay unit																																	
C4 PICASSO	Windscreen wiper	Windscreen wiper																																	
C4 PICASSO	ECU at the top of the steering column	ECU at the top of the steering column																																	
C4 PICASSO	Heatingventilation	Heating/ventilation																																	
C4 PICASSO	Instrument panel	Instrument panel																																	
C4 PICASSO	Radio or radiotelephone	Radio or radiotelephone																																	
C4 PICASSO	Passenger door electronics	Passenger door electronics																																	
C4 PICASSO	Passenger door electronics	Passenger door electronics																																	
C4 PICASSO	Driver's door electronics	Driver's door electronics																																	
C4 PICASSO	Driver's door electronics	Driver's door electronics																																	
C4 PICASSO	Rain and brightness sensor	Rain and brightness sensor																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	DCM3.5_BR2																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	SID807																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	MED17_4_4																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																	
C4 Cactus	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																	
C4 Cactus	Gearbox ECU	AM6 Euro5 automatic gearbox																																	
C4 Cactus	Gearbox ECU	AT6 Euro5 automatic gearbox																																	
C4 Cactus	Gearbox ECU	CFC300P gearbox																																	
C4 Cactus	Gearbox ECU	AL4 automatic gearbox																																	
C4 Cactus	Gearbox ECU	BVA_AM6_AT6_UDS																																	
C4 Cactus	Multiplexed additive adding pump ECU	Multiplexed additive adding pump ECU																																	
C4 Cactus	ABS or ESP ECU	ESP 81																																	
C4 Cactus	ABS or ESP ECU	ESP MK 100																																	

Vehicle	System 1	System 2	System 3	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Programming of the Confidential Code of the BSI	Programming of keys	Configuration View Only	Auto Configuration	Forced Regeneration Of Thhe Particulate Filter While Stationary	Forced regeneration of the Particulate filter while driving	Particulate Filter Replacement	Initialisation of the additive level when filling or replacing the additive reservoir	Longitudinal Acceleration Sensor Calibration	Configuration of the instrument panel	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset	Calibration of the longitudinal and lateral acceleration senso	Decalibration of the longitudinal and lateral acceleration sensor
C4 Cactus	ABS or ESP ECU	90 ESP																																	
C4 Cactus	Headlamp height adjuster directional headlamp	Headlamp height adjuster/ directional headlamp																																	
C4 Cactus	Built-In system interface	Built-In system interface																																	
C4 Cactus	Built-In system interface	Built-In system interface																																	
C4 Cactus	Power steering electric pump unit	GEP																																	
C4 Cactus	Power steering electric pump unit	DAE_BVH2																																	
C4 Cactus	Battery charge status unit	BECB_GEN2																																	
C4 Cactus	Electric secondary brake	FSE																																	
C4 Cactus	Engine relay unit	BSM																																	
C4 Cactus	Trailer relay unit	BSR																																	
C4 Cactus	Airbag ECU	RBG_UDS																																	
C4 Cactus	Airbag ECU	RBG_UDS																																	
C4 Cactus	Airbag ECU	SAC_AUTOLIV																																	
C4 Cactus	Instrument panel	COMBINE																																	
C4 Cactus	Instrument panel	COMBINE																																	
C4 Cactus	Rain-sunlight sensor	Rain and brightness sensor																																	
C4 Cactus	Rain-sunlight sensor	CDPL_UDS_HELLA																																	
C4 Cactus	Switch module at the steering wheel	COM2008P																																	
C4 Cactus	Switch module at the steering wheel	HDC																																	
C4 Cactus	Bodywork conversion unit	BTC																																	
C4 Cactus	Parking aid	AAS																																	
C4 Cactus	Additional heating	CHAUFF_ADD																																	
C4 Cactus	Telematics unit	SMEG_PLUS																																	
C4 Cactus	Anti-theft alarm	ALARME																																	
C4 Cactus	Rear air conditioning table	TAB_CLIM_AR																																	
C4 Cactus	Rain and brightness sensor	PLUIE_LUMINOSITE																																	
C4 Cactus	Supply protection and management unit	BPGA2010																																	
C4 Cactus	Door control pad	PDPC_UDS																																	
C4 Cactus	Air conditioning	BCC																																	
C4 Cactus	Touch screen	Touch screen																																	
C4 Cactus	Seat belts not fastened LED unit	TNB_2010																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	MED17_4_2	5FV MED17_4_2 EURO5																																
C-ELYSEE	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	DCM3.5_BR2																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	SID807																																	

Vehicle	System 1	System 2	System 3	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Programming of the Confidential Code of the BSI	Programming of keys	Configuration View Only	Auto Configuration	Forced Regeneration Of The Particulate Filter While Stationary	Forced regeneration of the Particulate filter while driving	Particulate Filter Replacement	Initialisation of the additive level when filling or replacing the additive reservoir	Longitudinal Acceleration Sensor Calibration	Configuration of the instrument panel	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset	Calibration of the longitudinal and lateral acceleration senso	Decalibration of the longitudinal and lateral acceleration sensor
C-ELYSEE	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	MED17_4_4																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																	
C-ELYSEE	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																	
C-ELYSEE	Gearbox ECU	BVA_AT8																																	
C-ELYSEE	Gearbox ECU	CFC300P																																	
C-ELYSEE	Gearbox ECU	BVA AM6 Euro5																																	
C-ELYSEE	Airbag	RBG_UDS																																	
C-ELYSEE	ABS_Electronic stability program	ESP 8.1																																	
C-ELYSEE	ABS_Electronic stability program	ABS 81																																	
C-ELYSEE	BSI	BSI2010																																	
C-ELYSEE	Power steering electric pump unit	GET																																	
C-ELYSEE	Battery charge status unit	Battery charge status unit																																	
C-ELYSEE	Electric secondary brake	Electric secondary brake																																	
C-ELYSEE	Trailer relay unit	Trailer relay unit																																	
C-ELYSEE	Windscreen wiper	Windscreen wiper																																	
C-ELYSEE	Switch module at the steering wheel	Switch module at the steering wheel																																	
C-ELYSEE	Heatingventilation	Heating/ventilation																																	
C-ELYSEE	Instrument panel	Instrument panel																																	
C-ELYSEE	Radio or radiotelephone	Radio or radiotelephone																																	
C-ELYSEE	Passenger door electronics	Passenger door electronics																																	
C-ELYSEE	Rain and brightness sensor	Rain and brightness sensor																																	
JUMPY	Injection(6th to 8th digit of VIN)	EDC16C3	9HU-DV6UTED4 - 90 CV																																
JUMPY	Injection(6th to 8th digit of VIN)	DCM3.5_BR2	AHZ-DW10CD-128CV																																
JUMPY	Anti-lock brake system	ABS 8.1																																	
JUMPY	Airbag	Airbag																																	
JUMPY	Trailer relay unit	Trailer relay unit																																	
JUMPY	Engine relay unit	Engine relay unit																																	
JUMPY	BSI	BSI																																	

Vehicle	System 1	System 2	System 3	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Programming of the Confidential Code of the BSI	Programming of keys	Configuration View Only	Auto Configuration	Forced Regeneration Of Thte Particulate Filter While Stationary	Forced regeneration of the Particulate filter while driving	Particulate Filter Replacement	Initialisation of the additive level when filling or replacing the additive reservoir	Longitudinal Acceleration Sensor Calibration	Configuration of the instrument panel	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset	Calibration of the longitudinal and lateral acceleration senso	Decalibration of the longitudinal and lateral acceleration sensor
JUMPY	Switch module under the steering wheel	Switch module under the steering wheel																																	
JUMPY	Bodywork conversion unit	Bodywork conversion unit																																	
Jumper	Engine(6th to 8th digit of VIN) Gearbox	PUMA	PUMA 4HV	V	V																														
Jumper	Engine(6th to 8th digit of VIN) Gearbox	PUMA	PUMA 4HU(120 or 130)	V	V																														
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC16C39	EDC16C39 TUB																																
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52	EDC17CP52 SOFIM EURO5																																
Jumper	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52_UDS 3.0 HDI 180CV E5	EDC17CP52_UDS 3.0 HDI 180CV E5			V	V	V	V	V	V	V	V																						
Jumper	Engine(6th to 8th digit of VIN) Gearbox	SID208	SID208				V			V				V	V	V	V	V																	
Jumper	ABSESP	ESP90_F																																	
Jumper	Power steering	SSCU																																	
Jumper	Airbag	Airbag																																	
Jumper	Built-In system interface	Built-In system interface																																	
Jumper	Built-In system interface	Built-In system interface																																	
Berlingo	Driving assistance Comfort	Parking aid																																	
Berlingo	Built-In system interface	Built-In system interface																	V	V															
Berlingo	Driver information Communication	Display / Telematics																																	
Berlingo	Driver information Communication	Radio																																	
Berlingo	Driver information Communication	CD Player																																	
Berlingo	Driver information Communication	Instrument panel																																	
Berlingo	Driver information Communication	Switching module below steering wheel (COM 2000)																																	
Berlingo	Airbags	Airbags																																	
Berlingo	VisibilityLighting	Switching module below steering wheel (COM 2000)																																	
Berlingo	VisibilityLighting	Rain/sunlight sensor																																	
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P																																
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																
Berlingo	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P																		V	V													
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801																																
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2																																
Berlingo	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																
Berlingo	Active Safety	ESP BOSCH 5.7																																	
Berlingo	Active Safety	ABS BOSCH 8																																	
Berlingo	Active Safety	ESP BOSCH 8																																	
Berlingo	Active Safety	ABS 8.1																																	
Berlingo	Active Safety	ESP 8.1																																	

Vehicle	System 1	System 2	System 3	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Programming of the Confidential Code of the BSI	Programming of keys	Configuration View Only	Auto Configuration	Forced Regeneration Of The Particulate Filter While Stationary	Forced regeneration of the Particulate filter while driving	Particulate Filter Replacement	Initialisation of the additive level when filling or replacing the additive reservoir	Longitudinal Acceleration Sensor Calibration	Configuration of the instrument panel	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset	Calibration of the longitudinal and lateral acceleration senso	Decalibration of the longitudinal and lateral acceleration sensor
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HW DV6BTED4 - 75 CV																				V	V	V										
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HX DV6AUTED4 - 90 CV																							V									
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HX-DV6ATED4 - 90 CV																							V									
Berlingo II	Injection(6th to 8th digit of VIN)	EDC16C3	9HZ-DV6TED4 FAP - 110 CV																							V									
Berlingo II	Injection(6th to 8th digit of VIN)	EDC17C10 BR2	9HN-DV6ETED																																
Berlingo II	Anti-lock brake system	ABS 8																																	
Berlingo II	Anti-lock brake system	ESP8.1_BOSCH																									V								
Berlingo II	Anti-lock brake system	ABS 81																																	
Berlingo II	Airbag	Airbag																																	
Berlingo II	Power steering electric pump unit	Power steering electric pump unit																																	
Berlingo II	Instrument panel	Instrument panel																										V							
Berlingo II	Radio	RD4																																	
Berlingo II	Radio	RD45																																	
Berlingo II	Rain sensor Brightness	Rain sensor / Brightness																																	
Berlingo II	Trailer relay unit	Trailer relay unit																																	
Berlingo II	Engine relay unit	Engine relay unit																																	
Berlingo II	Multiplexed additive pump	Multiplexed additive pump																																	
Berlingo II	Multifunction display	Multifunction display																																	
Berlingo II	BSI	BSI																	V	V															
Berlingo II	Switch module under the steering wheel	Switch module under the steering wheel																																	
Berlingo II	Switch module under the steering wheel	Switch module under the steering wheel																																	
NEMO	Engine(6th to 8th digit of VIN) Gearbox	EDC16C34																											V	V					
NEMO	Engine(6th to 8th digit of VIN) Gearbox	HDI_8DF3				V	V	V	V				V																		V	V	V		
NEMO	Engine(6th to 8th digit of VIN) Gearbox	BMF PUMA	BMF HDI 4C	V	V																														
NEMO	Engine(6th to 8th digit of VIN) Gearbox	EDC17CP52_UDS 3.0 HDI 180CV E5				V	V	V	V	V	V	V	V																						
NEMO	Engine(6th to 8th digit of VIN) Gearbox	SID208					V			V				V	V	V	V	V																	
NEMO	ABSESP	ESP 90_F																																V	V
NEMO	ABSESP	ESP 81																																	
NEMO	ABSESP	ABS 81																																	
NEMO	Built-In system interface	Built-In system interface																																	
NEMO	Built-In system interface	Built-In system interface																																	
NEMO	Built-In system interface	Built-In system interface																																	
NEMO	Airbag	Airbag																																	
NEMO	LDWS	LDWS																																	
NEMO	Instrument	Instrument																																	
NEMO	Parking control	Parking control																																	

Area	Vehicle	system 1	connector	system 2	DTC	CURRENT DATA	ACTUATION TEST	ECU INFORMATION
Taiwan	VARICA	1.2(C12S)	'1999~'2008	Engine-12Pin	V	V	V	V
Taiwan	VERYCA	1.2(C12S)	'2000~'2007	Engine-12Pin	V	V	V	V
Taiwan	VERYCA	1.2(C12S)	'2000~'2007	AT(Automatic Transmission)-16Pin	V	V	V	V
Taiwan	VERYCA	1.2(C12D)	'2003~'2014	SYSTEM SEARCH				
Taiwan	VERYCA	1.2(C12D)	'2003~'2014	Engine-12Pin	V	V	V	V
Taiwan	VERYCA	1.2(C12D)	'2003~'2014	AT(Automatic Transmission)-16Pin	V	V	V	V
Taiwan	VERYCA	1.3(4G13)	'2009~'2014	SYSTEM SEARCH				
Taiwan	VERYCA	1.3(4G13)	'2009~'2014	Engine-12Pin	V	V	V	V
Taiwan	VERYCA	1.3(4G13)	'2009~'2014	AT(Automatic Transmission)-16Pin	V	V	V	V
Taiwan	MAGIC	1.6(4G18)	'2001~'2008	SYSTEM SEARCH				
Taiwan	MAGIC	1.6(4G18)	'2001~'2008	Engine-12Pin	V	V	V	V
Taiwan	MAGIC	1.6(4G18)	'2001~'2008	AT(Automatic Transmission)-16Pin	V	V	V	V

Vehicle	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	[Erase]Air damper valve programming	[Erase]Average air temperature	[Erase]EGR valve programming	[Erase]Engine adaptives	[Erase]Exhaust injector circuit	[Erase]Flywheel target programming	[Erase]Fuel supply prevention	[Erase]Particle filter relative pressure sensor	[Erase]Preheater unit	[Erase]Proportional richness sensor programming	[Erase]Rail pressure sensor adaptives	ABS solenoid valve	Acceleration Sensor	Activation of Connectivity Services	Adaptive value-A/F ratio	Adaptive vaule tps	Adaptives after regeneration particle filter	Adaptives after replacing cabin filter	After Particle Filter Regeneration with the Diag Tool	After Replacement of the Particle Filter	After Replacing the Computer without having Saved Data	After replacment of the particle filter	Air bleeding	Air damper valve programming	Air flowmeter programming	Air path programming	Alcohol level prog.	Anti-Theft Alarm Trigger S/W	Auto-adaptives	Automatic Relocking	Bleed Hydraulic Unit and Braking Circuits	Bleeding	Brake Lining Friction Learning	Brake Pressure Offset Sensor	Cabin filter regeneration	Cabin Filter Regeneration (DPF regeneration)	Calculate battery wear counters	Camshaft sensor programming	Caravan towing distance	Catalytic converter test	Check target teeth	Computer Initialisation	Computer Reinitialisation	Computer Reset	Configuration	Cruise control/speed limiter programming	Decrement idle speed	Distance before next oil change	ECU Memory	EGR adaptives	EGR Programming	EGR valve	EGR Valve (reinitialisation)	EGR valve programming
LOGAN	LOGAN	Injection	V	V	V	V																	V	V						V											V																					V
LOGAN	LOGAN	GAS Injection	V	V	V	V																																																							
LOGAN	LOGAN	A.B.S.	V	V	V	V																															V											V													
LOGAN	LOGAN	Variable P.A.S.	V	V	V	V																																																							
LOGAN	LOGAN	UCH	V	V	V	V																														V															V									
LOGAN	LOGAN	Airbag / Pretensioners	V	V	V	V																																													V									
LOGAN	LOGAN II	Injection	V	V	V	V	V		V	V		V	V			V	V							V							V		V								V			V		V					V					V				
LOGAN	LOGAN II	A.B.S.	V	V	V	V													V																					V							V													
LOGAN	LOGAN II	Instrument Panel	V	V	V	V																																																							
LOGAN	LOGAN II	UCH	V	V	V	V																																																							
LOGAN	LOGAN II	Airbag / Pretensioners	V	V	V	V																																																							
LOGAN	LOGAN II	Air Conditioning	V	V	V	V																																															V									
LOGAN	LOGAN II	Variable P.A.S.	V	V	V	V																																																							
SANDERO	SANDERO	Injection	V	V	V	V																																																							
SANDERO	SANDERO	GAS Injection	V	V	V	V																																																							
SANDERO	SANDERO	A.B.S.	V	V	V	V																															V											V													
SANDERO	SANDERO	Variable P.A.S.	V	V	V	V																																																							
SANDERO	SANDERO	UCH	V	V	V	V																																													V									
SANDERO	SANDERO	Airbag / Pretensioners	V	V	V	V																																													V									
DUSTER	DUSTER	Injection	V	V	V	V																								V		V	V											V								V									V
DUSTER	DUSTER	Automatic Gearbox	V	V	V	V																													V																											
DUSTER	DUSTER	4 Wheel Drive	V	V	V	V																																											V												
DUSTER	DUSTER	Radio	V	V	V	V																																																						
DUSTER	DUSTER	A.B.S.	V	V	V	V																															V											V													
DUSTER	DUSTER	UCH	V	V	V	V																																																							
DUSTER	DUSTER	Airbag / Pretensioners	V	V	V	V																																																							
DUSTER	DUSTER	Variable P.A.S.	V	V	V	V																																																								
DUSTER	DUSTER PH2	Injection	V	V	V	V	V		V	V		V	V	V		V	V							V							V		V								V			V		V					V					V				
DUSTER	DUSTER PH2	A.B.S.	V	V	V	V													V																					V							V													
DUSTER	DUSTER PH2	Instrument Panel	V	V	V	V																																																							
DUSTER	DUSTER PH2	UCH	V	V	V	V																																																							
DUSTER	DUSTER PH2	Airbag / Pretensioners	V	V	V	V																																																							
DUSTER	DUSTER PH2	Variable P.A.S.	V	V	V	V																																																							
DOKKER	DOKKER	Injection	V	V	V	V							V			V																	V											V								V					V				
DOKKER	DOKKER	A.B.S.	V	V	V	V																																			V							V													
DOKKER	DOKKER	Instrument Panel	V	V	V	V																																																							
DOKKER	DOKKER	UCH	V	V	V	V																																																							
DOKKER	DOKKER	Airbag / Pretensioners	V	V	V	V																																																							
DOKKER	DOKKER	Variable P.A.S.	V	V	V	V																																																							

| Vehicle | System 1 | System 2 | Engine Adaptives | Engine parameter adaptives | Enter injector codes | Enter injector codes (4 line command 4cylinder) | Erase auto-adaptive values | Erase ECU memory | Erase EGR adaptives | Erase idle regulation adaptives | Erase Pressure regulation adaptives | Erase programmed values | Erasing | Exhaust injector circuit | Flywheel Target Programming | Fuel flow regulator | Fuel gauge calibration | Fuel Pump Programming | Fuel Supply Prevention | Hill Start | Ignition coil adaptive | Immobilizer | Increment of idle speed | Injection prohibition | Injection pump adatatives | Injector Adaptives | Injector adaptives No.1 | Injector adaptives No.2 | Injector adaptives No.3 | Injector adaptives No.4 | Injector Coding | Injector cylinder 1 | Injector cylinder 2 | Injector cylinder 3 | Injector cylinder 4 | Injectors (reinitialisation) | Inlet flap | Inlet Flap (reinitialisation) | Lock Computer | Lock injector control | Longitudinal acceleration sensor offset | Manifold pressure sensor programming | modification of parameters after initialisation | Number of starting cycles | Odometer in Km | Odometer in Miles | Oil change interval in KM | Oil change interval in Months | Oil change range : current value in KM | Oil change range : current value in Months | Oil change range : current value in km | Oil change range:current value in MONTHS | Particle filter relative pressure sensor | Passenger air bag locking mode | Pinking sensor programming | Pressure regularion adaptives | Prevention of electrical consumers | Program clutch open position | Programmed Values | Programming of seat stops |
|---|---|---

Vehicle	System 1	System 2	Programming Reinitialisation	Programming selection/Engaging zones	Programming the Codes of the Four Valves	Programming Throttle Limits	Proportional Richness Sensor Programming	Rail pressure sensor adaptives	Read Configuration	Rear Brake Unit Initialisation	Rear Brake Unit Repositioning	Refilling new pump body	Reset	Reset Oil Change Counter	Resetting Internal Protection	Restart the computer	Richness Regulation Programming	Sensor Configuration	Sensor offsets	Shoe Lining Energy Counter	Slope Sensor Adjustment	Speed Index	Start OBD test:catalytic converter	Start OBD test:O2 sensors	Steering Angle Sensor Initialisation	Steering Wheel Angle Offset Sensor	Steering Wheel Angle Sensor	Stop & start function configuration	Stop Fuel Supply Prevention	Transverse Acceleration Offset Sensor	Turbocharging programming	Unlock Computer	Unlock Injector Control	Update odometer	Valve set selection	Van fast idle speed decrease	Van fast idle speed increase	Vehicle function programming	Vehicle parameters	With airconditioning	With boiler	With passenger compartment heating resistor	With power steering electric pump unit	With thermoplungers	Without airconditioning	Without boiler	Without passenger compartment heating resistor	Without power steering electric pump unit	Without thermoplungers	Write configuration	Write configuration [Flashing buzzer]	Write date new clutch fitted	Write Date of Last After Sales Operation	Write transmission oil change date	Write V.I.N	Originally fitted perimetric protection	De-ice function	Starter relay request	Illuminate hazard lamps upon impact	Raid function authorisation by diag
LOGAN	LOGAN	Injection							V																				V																																		
LOGAN	LOGAN	GAS Injection							V																																									V												
LOGAN	LOGAN	A.B.S.																				V																V														V								
LOGAN	LOGAN	Variable P.A.S.																																																		V								
LOGAN	LOGAN	UCH																																																					V	V	V	V	V
LOGAN	LOGAN	Airbag / Pretensioners																														V																														
LOGAN	LOGAN II	Injection				V	V		V								V																																						V						
LOGAN	LOGAN II	A.B.S.							V				V									V				V	V			V																							V		V						
LOGAN	LOGAN II	Instrument Panel																																V																											
LOGAN	LOGAN II	UCH							V																																									V				V						
LOGAN	LOGAN II	Airbag / Pretensioners							V									V														V																														
LOGAN	LOGAN II	Air Conditioning																																																					V						
LOGAN	LOGAN II	Variable P.A.S.																																																		V		V						
SANDERO	SANDERO	Injection							V																																																				
SANDERO	SANDERO	GAS Injection							V																																																				
SANDERO	SANDERO	A.B.S.																				V				V												V														V								
SANDERO	SANDERO	Variable P.A.S.																																																		V								
SANDERO	SANDERO	UCH																																																										
SANDERO	SANDERO	Airbag / Pretensioners																														V																														
DUSTER	DUSTER	Injection	V			V		V	V								V						V	V					V																																	
DUSTER	DUSTER	Automatic Gearbox																																																		V	V							
DUSTER	DUSTER	4 Wheel Drive																				V																												V										
DUSTER	DUSTER	Radio							V																																											V								
DUSTER	DUSTER	A.B.S.																	V			V																V														V								
DUSTER	DUSTER	UCH							V																																										V								
DUSTER	DUSTER	Airbag / Pretensioners							V																							V																														
DUSTER	DUSTER	Variable P.A.S.							V																																											V								
DUSTER	DUSTER PH2	Injection				V	V		V								V																																						V						
DUSTER	DUSTER PH2	A.B.S.							V				V													V	V			V																							V		V						
DUSTER	DUSTER PH2	Instrument Panel																																V																											
DUSTER	DUSTER PH2	UCH							V																																									V				V						
DUSTER	DUSTER PH2	Airbag / Pretensioners							V																							V																														
DUSTER	DUSTER PH2	Variable P.A.S.																																																		V		V						
DOKKER	DOKKER	Injection				V	V		V								V																																						V						
DOKKER	DOKKER	A.B.S.							V																	V	V			V																							V		V						
DOKKER	DOKKER	Instrument Panel																																V																											
DOKKER	DOKKER	UCH							V																																									V				V						
DOKKER	DOKKER	Airbag / Pretensioners							V									V														V																														
DOKKER	DOKKER	Variable P.A.S.																																																		V		V						

Vehicle	System 1	System 2	vehicle locked by autolock when driving	Timer courtesy light	Heated rear screen when driving	Airbag	Courtesy light timer	Key type	Second fitting alarm	Radio frequency function	Overspeed alarm for arabia	Engine type	Configuration privee 31	Interval variation with speed	Locking with key	Seat belt unfastened detection	Verrou logicel (software lock)	Central locking button type	Note Oil Wear Counter	With Swirl Flap	Oil Vapour Heater	Upstream Oxygen Sensor	Waste Gate Regulation	Stop And Start Function	Number Of Starting Cycles [RZ079]	Alternator Setpoint Voltage	Number Of Starting Cycles [VP343]	Configuration PRIVEE29	Air Flowmeter Programming	Adaptives On Air Intake Flap Fault	Particle Filter Pressure Diff. Sensor	Engine Adaptives [RZ002]	Engine Adaptives [RZ003]	Low Pressure EGR Valve Programming	Exhaust Flap Low Setting	High Pressure Pump Counter [RZ097]	Injection Pump Adaptatives [RZ077]	Injection Pump Adaptatives [RZ093]	Number Of Starting 1	Number Of Starting 2	Number Of Starting 3	Number Of Starting 4	Number of Starting Cycle [VP343]	High Pressure Pump Counter [VP344]	Flywheel Target Programming [RZ037]	Flywheel Target Programming [RZ061]	Starter Adaptatives	Injection Time Programming	EGR Bypass Programming	Cylinder 1 Injector Code	Cylinder 2 Injector Code	Cylinder 3 Injector Code	Cylinder 4 Injector Code	Speedo index	Hill Start	Bleed rear R/H wheel	Bleed rear L/H wheel	Bleed front R/H wheel	Bleed front L/H wheel	R/H Rear Wheel Solenoid Valves
LOGAN	LOGAN	Injection																																																										
LOGAN	LOGAN	GAS Injection																																																										
LOGAN	LOGAN	A.B.S.																																																										
LOGAN	LOGAN	Variable P.A.S.																																																										
LOGAN	LOGAN	UCH	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																																										
LOGAN	LOGAN	Airbag / Pretensioners																																																										
LOGAN	LOGAN II	Injection																		V	V	V	V	V	V	V	V			V	V		V	V	V	V	V	V	V	V	V	V	V			V	V	V	V	V	V	V								
LOGAN	LOGAN II	A.B.S.																																																					V	V	V	V	V	V
LOGAN	LOGAN II	Instrument Panel																																																										
LOGAN	LOGAN II	UCH																																																										
LOGAN	LOGAN II	Airbag / Pretensioners																																																										
LOGAN	LOGAN II	Air Conditioning																																																										
LOGAN	LOGAN II	Variable P.A.S.																																																										
SANDERO	SANDERO	Injection																																																										
SANDERO	SANDERO	GAS Injection																																																										
SANDERO	SANDERO	A.B.S.																																																										
SANDERO	SANDERO	Variable P.A.S.																																																										
SANDERO	SANDERO	UCH																																																										
SANDERO	SANDERO	Airbag / Pretensioners																																																										
DUSTER	DUSTER	Injection																																																										
DUSTER	DUSTER	Automatic Gearbox																																																										
DUSTER	DUSTER	4 Wheel Drive																																																										
DUSTER	DUSTER	Radio																																																										
DUSTER	DUSTER	A.B.S.																																																										
DUSTER	DUSTER	UCH																																																										
DUSTER	DUSTER	Airbag / Pretensioners																																																										
DUSTER	DUSTER	Variable P.A.S.																																																										
DUSTER	DUSTER PH2	Injection																					V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V			V	V	V	V	V
DUSTER	DUSTER PH2	A.B.S.																																																					V	V	V	V	V	V
DUSTER	DUSTER PH2	Instrument Panel																																																										
DUSTER	DUSTER PH2	UCH																																																										
DUSTER	DUSTER PH2	Airbag / Pretensioners																																																										
DUSTER	DUSTER PH2	Variable P.A.S.																																																										
DOKKER	DOKKER	Injection																					V	V	V						V		V	V	V				V	V	V	V																		
DOKKER	DOKKER	A.B.S.																																																					V	V	V	V	V	V
DOKKER	DOKKER	Instrument Panel																																																										
DOKKER	DOKKER	UCH																							V											V																								
DOKKER	DOKKER	Airbag / Pretensioners																																																										
DOKKER	DOKKER	Variable P.A.S.																																																										

Vehicle	System 1	System 2	L/H Rear Wheel Solenoid Valves	R/H Front Wheel Solenoid Valves	L/H Front Wheel Solenoid Valves	Language Version	ADAC Display Type	Odometer in Km	Odometer in Miles	Hazard Warning Lights Illumination by ABS	Second Fitting Alarm	Alarm	Vehicle Type	Gearbox Type	Fuel Type	Trajectory Control	Tyre Pressure Monitoring	Distance Units	Overspeed Function - Ariabia	Lights Automatic Illumination	Particle Filter	Fuel Sender Calibration (Europe)	Fuel Sender Calibration (DOI)	Steering wheel angle sensor programming	Overspeed Alarm	Seat Belt Warning Module	Personalised oil change Frequency	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	Distance Before Next Oil Change Configuration	Mode Number	Static Test	Vacuum Pump Operation Request
LOGAN	LOGAN	Injection																																	
LOGAN	LOGAN	GAS Injection																																	
LOGAN	LOGAN	A.B.S.																																	
LOGAN	LOGAN	Variable P.A.S.																																	
LOGAN	LOGAN	UCH																																	
LOGAN	LOGAN	Airbag / Pretensioners																																	
LOGAN	LOGAN II	Injection																																	
LOGAN	LOGAN II	A.B.S.	V	V	V																														
LOGAN	LOGAN II	Instrument Panel																																	
LOGAN	LOGAN II	UCH								V	V	V																							
LOGAN	LOGAN II	Airbag / Pretensioners																																	
LOGAN	LOGAN II	Air Conditioning																																	
LOGAN	LOGAN II	Variable P.A.S.																																	
SANDERO	SANDERO	Injection																																	
SANDERO	SANDERO	GAS Injection																																	
SANDERO	SANDERO	A.B.S.																																	
SANDERO	SANDERO	Variable P.A.S.																																	
SANDERO	SANDERO	UCH																																	
SANDERO	SANDERO	Airbag / Pretensioners																																	
DUSTER	DUSTER	Injection																																	
DUSTER	DUSTER	Automatic Gearbox																																	
DUSTER	DUSTER	4 Wheel Drive																																	
DUSTER	DUSTER	Radio																																	
DUSTER	DUSTER	A.B.S.																																	
DUSTER	DUSTER	UCH																																	
DUSTER	DUSTER	Airbag / Pretensioners																																	
DUSTER	DUSTER	Variable P.A.S.																																	
DUSTER	DUSTER PH2	Injection	V	V	V																													V	V
DUSTER	DUSTER PH2	A.B.S.	V	V	V																														
DUSTER	DUSTER PH2	Instrument Panel																																	
DUSTER	DUSTER PH2	UCH								V	V	V																							
DUSTER	DUSTER PH2	Airbag / Pretensioners																																	
DUSTER	DUSTER PH2	Variable P.A.S.																																	
DOKKER	DOKKER	Injection																																	
DOKKER	DOKKER	A.B.S.	V	V	V																														
DOKKER	DOKKER	Instrument Panel																																	
DOKKER	DOKKER	UCH								V	V	V																							
DOKKER	DOKKER	Airbag / Pretensioners																																	
DOKKER	DOKKER	Variable P.A.S.																																	

Area	Vehicle	Chassis Type	Year	System 1	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	CVT ECU Initial Learning	Radar Cruise Optical Adjustment	Secondary Repair Air Bleeding Drive	Roof ECU Initialization	Antenna Connection Diagnosis	Change Keyless Go ECU configuration	Engine Start Counter	Front Camera Optical Axis Adjustment	Tertiary Repair Air Bleeding	Laser Radar Axis Adjust	Steering Angle sensor Initial Learning	Antena connection check	Key Free Setting	Smart Communication Test	Transponder Communication Test	Body ECU Reset	Wireless communication test	Eco Run ECU Initial Learning
International	-	-	16P CONNECTOR	EFI(Engine)	V	V	V	V																		
International	-	-	16P CONNECTOR	AT	V	V	V																			
International	-	-	16P CONNECTOR	CVT	V	V	V	V	V																	
International	-	-	16P CONNECTOR	eco IDLE	V	V	V	V																		V
International	-	-	16P CONNECTOR	ERS(Idle Stop)	V			V																		
International	-	-	16P CONNECTOR	POWER(PUSH START)	V																					
International	-	-	16P CONNECTOR	ACC(Adaptive Cruise Control)	V					V																
International	-	-	16P CONNECTOR	IMG(Lane Keeping Assist)	V	V		V								V										
International	-	-	16P CONNECTOR	DSS(Precrash Safety System)	V			V																		
International	-	-	16P CONNECTOR	ABS	V	V	V				V															
International	-	-	16P CONNECTOR	ABS/VSC	V	V	V	V			V						V									
International	-	-	16P CONNECTOR	DVS(Daihatsu Vehicle Stability control system)	V	V	V																			
International	-	-	16P CONNECTOR	4WD(4 Wheel Drive)	V	V																				
International	-	-	16P CONNECTOR	EPS(Electric Power Steering)	V	V		V																		
International	-	-	16P CONNECTOR	Steering Angle Sensor		V													V							
International	-	-	16P CONNECTOR	SRS AIRBAG	V			V																		
International	-	-	16P CONNECTOR	Body	V	V	V	V												V	V	V	V	V	V	
International	-	-	16P CONNECTOR	Auto Leveling	V	V	V	V																		
International	-	-	16P CONNECTOR	PCB	V	V		V										V								
International	-	-	16P CONNECTOR	Sonrar	V	V		V																		
International	-	-	16P CONNECTOR	PSD(Power Sliding Door-Right)	V	V	V	V																		
International	-	-	16P CONNECTOR	PSD(Power Sliding Door-Left)	V	V	V	V																		
International	-	-	16P CONNECTOR	Combi Switch		V		V																		
International	-	-	16P CONNECTOR	ITC(Intergrated Timer Control)	V	V	V	V																		
International	-	-	16P CONNECTOR	Immobilizer	V																					
International	-	-	16P CONNECTOR	KFS(Key Free System)	V	V	V	V																		
International	-	-	16P CONNECTOR	Roof	V	V	V					V														
International	-	-	16P CONNECTOR	Pre-crash Seat Belt(Driver Seat)	V			V																		
International	-	-	16P CONNECTOR	Pre-crash Seat Belt(Passenger Seat)	V			V																		
International	-	-	16P CONNECTOR	Meter	V	V	V	V																		

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
General(CAN Bus)	ALL	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
General(CAN Bus)	ALL	ABS (Anti Lock Brake System)	V	V	V	V				V																																			V	V	V	V
General(CAN Bus)	ALL	ACC (Adaptive Cruise Control)	V			V																																										
General(CAN Bus)	ALL	ADCM (Adaptive Damper Control Module)	V			V																																										
General(CAN Bus)	ALL	AFLS (Adaptive Front Light System)	V			V																																										
General(CAN Bus)	ALL	AHBM (Automatic High Beam)	V			V																																										
General(CAN Bus)	ALL	AMP (Audio)	V	V		V																																										
General(CAN Bus)	ALL	BCM (Body Control Module)	V			V																																										
General(CAN Bus)	ALL	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
General(CAN Bus)	ALL	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
General(CAN Bus)	ALL	CGW (Central Gateway)	V	V	V	V																																										
General(CAN Bus)	ALL	DDM (Drivers Door Module)	V	V	V	V																																										
General(CAN Bus)	ALL	DTCM (Drive Train Control Module)	V			V																																										
General(CAN Bus)	ALL	EDM (Electronic Damper Module)	V			V																																										
General(CAN Bus)	ALL	EOM (Electric Overhead Module)	V	V	V	V																																										
General(CAN Bus)	ALL	EPB (Electrical Parking Brake)	V	V		V																																										
General(CAN Bus)	ALL	EPS (Electric Power Steering)	V			V																																										
General(CAN Bus)	ALL	ESM (Electronic Shifter Module)	V			V																																										
General(CAN Bus)	ALL	FFCM (Front Facing Camera Module)	V	V	V	V																																										
General(CAN Bus)	ALL	HFM (Hands Free Module)	V	V	V	V																																										
General(CAN Bus)	ALL	HSM (Heated Seat Module)	V			V																																										
General(CAN Bus)	ALL	HVAC (Heat Vent A/C)	V	V	V	V																																										
General(CAN Bus)	ALL	ICS (Integrated Center Stack)	V			V																																										
General(CAN Bus)	ALL	IPC (Instrument Panel Cluster)	V			V																																										
General(CAN Bus)	ALL	ITM (Intrusion)	V			V																																										
General(CAN Bus)	ALL	LBSS (Left Blind Spot Sensor)	V			V																																										
General(CAN Bus)	ALL	LRSM (Light Rain Sensor Module)	V			V																																										
General(CAN Bus)	ALL	MSMD (Memory Seet Module)	V	V	V	V																																										
General(CAN Bus)	ALL	OCM (Occupant Classification Module)	V			V																																										
General(CAN Bus)	ALL	ORC (Occupant Restraint Control)	V	V		V																																										
General(CAN Bus)	ALL	PDM (Passenger Door Module)	V	V	V	V																																										
General(CAN Bus)	ALL	PLM (Power Liftgate Module)	V			V																																										
General(CAN Bus)	ALL	PTS (Park Assist Module)	V			V																																										
General(CAN Bus)	ALL	RADIO (Radio)	V	V		V																																										
General(CAN Bus)	ALL	RBSS (Right Blind Spot Sensor)	V			V																																										
General(CAN Bus)	ALL	RFH (Radio Frequency Hub)	V			V																																										
General(CAN Bus)	ALL	SAS (Steering Angle Sensor)	V	V	V	V																																										
General(CAN Bus)	ALL	SCM (Steering Column Module)	V			V																																										
General(CAN Bus)	ALL	SDAR (Satellite Radio)	V			V																																										
General(CAN Bus)	ALL	SUNR (Sunroof Module)	V			V																																										
General(CAN Bus)	ALL	TCM (Transmission Control Module)	V	V	V	V	V																															V	V	V	V	V	V					
General(CAN Bus)	ALL	TGW (Telematics Gateway)	V			V																																										
General(CAN Bus)	ALL	TPM (Tire Pressure Monitor)	V			V																																										
General(CAN Bus)	ALL	VES3 (Vidio Entertainment System 3)	V			V																																										
General(CAN Bus)	ALL	WCM(Wireless Control Modules)	V	V	V	V																																										
DURANGO	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DURANGO	2016	ABS (Anti Lock Brake System)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
DURANGO	2016	ACC (Adaptive Cruise Control)	V			V																																										
DURANGO	2016	AMP (Audio)	V			V																																										
DURANGO	2016	BCM (Body Control Module)	V			V																																										
DURANGO	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
DURANGO	2016	CGW (Central Gateway)	V			V																																										
DURANGO	2016	DDM (Drivers Door Module)	V			V																																										
DURANGO	2016	DTCM (Drive Train Control Module)	V			V																																										
DURANGO	2016	EDM (Electronic Damper Module)	V			V																																										
DURANGO	2016	EPS (Electric Power Steering)	V			V																																										
DURANGO	2016	ESM (Electronic Shifter Module)	V			V																																										
DURANGO	2016	FFCM (Front Facing Camera Module)	V	V	V	V																																										
DURANGO	2016	HSM (Heated Seat Module)	V			V																																										
DURANGO	2016	HVAC (Heat Vent A/C)	V			V																																										
DURANGO	2016	ICS (Integrated Center Stack)	V			V																																										
DURANGO	2016	IPC (Instrument Panel Cluster)	V			V																																										
DURANGO	2016	ITM (Intrusion)	V			V																																										
DURANGO	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
DURANGO	2016	MSMD (Memory Seet Module)	V			V																																										
DURANGO	2016	ORC (Occupant Restraint Control)	V			V																																										
DURANGO	2016	PDM (Passenger Door Module)	V			V																																										
DURANGO	2016	PLM (Power Liftgate Module)	V			V																																										
DURANGO	2016	PTS (Park Assist Module)	V			V																																										
DURANGO	2016	RADIO (Radio)	V			V																																										
DURANGO	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
DURANGO	2016	RFH (Radio Frequency Hub)	V			V																																										
DURANGO	2016	SCM (Steering Column Module)	V			V																																										
DURANGO	2016	TCM (Transmission Control Module)	V			V																																										
DURANGO	2016	TPM (Tire Pressure Monitor)	V			V																																										
DURANGO	2016	VES3 (Vidio Entertainment System 3)	V			V																																										
DURANGO	2016	WCM(Wireless Control Modules)	V			V																																										
DURANGO	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DURANGO	2015	ABS (Anti Lock Brake System)	V			V																																										
DURANGO	2015	ACC (Adaptive Cruise Control)	V			V																																										
DURANGO	2015	AMP (Audio)	V			V																																										
DURANGO	2015	BCM (Body Control Module)	V			V																																										
DURANGO	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
DURANGO	2015	CGW (Central Gateway)	V			V																																										
DURANGO	2015	DDM (Drivers Door Module)	V			V																																										
DURANGO	2015	DTCM (Drive Train Control Module)	V			V																																										
DURANGO	2015	EDM (Electronic Damper Module)	V			V																																										
DURANGO	2015	EPS (Electric Power Steering)	V			V																																										
DURANGO	2015	ESM (Electronic Shifter Module)	V			V																																										
DURANGO	2015	FFCM (Front Facing Camera Module)	V	V	V	V																																										
DURANGO	2015	HSM (Heated Seat Module)	V			V																																										
DURANGO	2015	HVAC (Heat Vent A/C)	V			V																																										
DURANGO	2015	ICS (Integrated Center Stack)	V			V																																										
DURANGO	2015	IPC (Instrument Panel Cluster)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
DURANGO	2015	ITM (Intrusion)	V			V																																										
DURANGO	2015	LBSS (Left Blind Spot Sensor)	V			V																																										
DURANGO	2015	MSMD (Memory Seet Module)	V			V																																										
DURANGO	2015	ORC (Occupant Restraint Control)	V			V																																										
DURANGO	2015	PDM (Passenger Door Module)	V			V																																										
DURANGO	2015	PLM (Power Liftgate Module)	V			V																																										
DURANGO	2015	PTS (Park Assist Module)	V			V																																										
DURANGO	2015	RADIO (Radio)	V			V																																										
DURANGO	2015	RBSS (Right Blind Spot Sensor)	V			V																																										
DURANGO	2015	RFH (Radio Frequency Hub)	V			V																																										
DURANGO	2015	SCM (Steering Column Module)	V			V																																										
DURANGO	2015	TCM (Transmission Control Module)	V			V																																										
DURANGO	2015	TPM (Tire Pressure Monitor)	V			V																																										
DURANGO	2015	VES3 (Vidio Entertainment System 3)	V			V																																										
DURANGO	2015	WCM(Wireless Control Modules)	V			V																																										
DURANGO	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DURANGO	2014	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DURANGO	2014	ACC (Adaptive Cruise Control)	V			V																																										
DURANGO	2014	AMP (Audio)	V	V		V																																										
DURANGO	2014	DDM (Drivers Door Module)	V	V	V	V																																										
DURANGO	2014	DTCM (Drive Train Control Module)	V			V																																										
DURANGO	2014	ESM (Electronic Shifter Module)	V			V																																										
DURANGO	2014	FFCM (Front Facing Camera Module)	V	V	V	V																																										
DURANGO	2014	HSM (Heated Seat Module)	V			V																																										
DURANGO	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
DURANGO	2014	ITM (Intrusion)	V			V																																										
DURANGO	2014	ORC (Occupant Restraint Control)	V	V		V																																										
DURANGO	2014	PDM (Passenger Door Module)	V	V	V	V																																										
DURANGO	2014	PLM (Power Liftgate Module)	V			V																																										
DURANGO	2014	PTS (Park Assist Module)	V			V																																										
DURANGO	2014	RADIO (Radio)	V	V		V																																										
DURANGO	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DURANGO	2014	CGW (Central Gateway)	V	V	V	V																																										
DURANGO	2014	TPM (Tire Pressure Monitor)	V			V																																										
DURANGO	2014	VES3 (Vidio Entertainment System 3)	V			V																																										
DURANGO	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DURANGO	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DURANGO	2013	ACC (Adaptive Cruise Control)	V			V																																										
DURANGO	2013	AHBM (Automatic High Beam)	V			V																																										
DURANGO	2013	AMP (Audio)	V	V		V																																										
DURANGO	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DURANGO	2013	DTCM (Drive Train Control Module)	V			V																																										
DURANGO	2013	ESM (Electronic Shifter Module)	V			V																																										
DURANGO	2013	HFM (Hands Free Module)	V	V	V	V																																										
DURANGO	2013	HSM (Heated Seat Module)	V			V																																										
DURANGO	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
DURANGO	2013	ITM (Intrusion)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
DURANGO	2013	MSMD (Memory Seet Module)	V	V	V	V																																										
DURANGO	2013	ORC (Occupant Restraint Control)	V	V		V																																										
DURANGO	2013	PLM (Power Liftgate Module)	V			V																																										
DURANGO	2013	PTS (Park Assist Module)	V			V																																										
DURANGO	2013	RADIO (Radio)	V	V		V																																										
DURANGO	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
DURANGO	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DURANGO	2013	CGW (Central Gateway)	V	V	V	V																																										
DURANGO	2013	TPM (Tire Pressure Monitor)	V			V																																										
DURANGO	2013	VES3 (Vidio Entertainment System 3)	V			V																																										
DURANGO	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
DURANGO	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DURANGO	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DURANGO	2012	ACC (Adaptive Cruise Control)	V			V																																										
DURANGO	2012	AHBM (Automatic High Beam)	V			V																																										
DURANGO	2012	AMP (Audio)	V	V		V																																										
DURANGO	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DURANGO	2012	DTCM (Drive Train Control Module)	V			V																																										
DURANGO	2012	ESM (Electronic Shifter Module)	V			V																																										
DURANGO	2012	HFM (Hands Free Module)	V	V	V	V																																										
DURANGO	2012	HSM (Heated Seat Module)	V			V																																										
DURANGO	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
DURANGO	2012	ITM (Intrusion)	V			V																																										
DURANGO	2012	MSMD (Memory Seet Module)	V	V	V	V																																										
DURANGO	2012	ORC (Occupant Restraint Control)	V	V		V																																										
DURANGO	2012	PLM (Power Liftgate Module)	V			V																																										
DURANGO	2012	PTS (Park Assist Module)	V			V																																										
DURANGO	2012	RADIO (Radio)	V	V		V																																										
DURANGO	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
DURANGO	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DURANGO	2012	CGW (Central Gateway)	V	V	V	V																																										
DURANGO	2012	TPM (Tire Pressure Monitor)	V			V																																										
DURANGO	2012	VES3 (Vidio Entertainment System 3)	V			V																																										
DURANGO	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
DURANGO	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DURANGO	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DURANGO	2011	ACC (Adaptive Cruise Control)	V			V																																										
DURANGO	2011	AHBM (Automatic High Beam)	V			V																																										
DURANGO	2011	AMP (Audio)	V	V		V																																										
DURANGO	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DURANGO	2011	DTCM (Drive Train Control Module)	V			V																																										
DURANGO	2011	ESM (Electronic Shifter Module)	V			V																																										
DURANGO	2011	HFM (Hands Free Module)	V	V	V	V																																										
DURANGO	2011	HSM (Heated Seat Module)	V			V																																										
DURANGO	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
DURANGO	2011	ITM (Intrusion)	V			V																																										
DURANGO	2011	MSMD (Memory Seet Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
DURANGO	2011	ORC (Occupant Restraint Control)	V	V		V																																										
DURANGO	2011	PLM (Power Liftgate Module)	V			V																																										
DURANGO	2011	PTS (Park Assist Module)	V			V																																										
DURANGO	2011	RADIO (Radio)	V	V		V																																										
DURANGO	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
DURANGO	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DURANGO	2011	CGW (Central Gateway)	V	V	V	V																																										
DURANGO	2011	TPM (Tire Pressure Monitor)	V			V																																										
DURANGO	2011	VES3 (Vidio Entertainment System 3)	V			V																																										
DURANGO	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
DURANGO	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DURANGO	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DURANGO	2009	AMP (Audio)	V	V		V																																										
DURANGO	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DURANGO	2009	DDM (Drivers Door Module)	V	V	V	V																																										
DURANGO	2009	EOM (Electric Overhead Module)	V	V	V	V																																										
DURANGO	2009	HFM (Hands Free Module)	V	V	V	V																																										
DURANGO	2009	HSM (Heated Seat Module)	V			V																																										
DURANGO	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
DURANGO	2009	MSMD (Memory Seet Module)	V	V	V	V																																										
DURANGO	2009	ORC (Occupant Restraint Control)	V	V		V																																										
DURANGO	2009	PDM (Passenger Door Module)	V	V	V	V																																										
DURANGO	2009	PLM (Power Liftgate Module)	V			V																																										
DURANGO	2009	PTS (Park Assist Module)	V			V																																										
DURANGO	2009	RADIO (Radio)	V	V		V																																										
DURANGO	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
DURANGO	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DURANGO	2009	CGW (Central Gateway)	V	V	V	V																																										
DURANGO	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
DURANGO	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
DURANGO	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DURANGO	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DURANGO	2008	AMP (Audio)	V	V		V																																										
DURANGO	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DURANGO	2008	DDM (Drivers Door Module)	V	V	V	V																																										
DURANGO	2008	EOM (Electric Overhead Module)	V	V	V	V																																										
DURANGO	2008	HFM (Hands Free Module)	V	V	V	V																																										
DURANGO	2008	HSM (Heated Seat Module)	V			V																																										
DURANGO	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
DURANGO	2008	MSMD (Memory Seet Module)	V	V	V	V																																										
DURANGO	2008	ORC (Occupant Restraint Control)	V	V		V																																										
DURANGO	2008	PDM (Passenger Door Module)	V	V	V	V																																										
DURANGO	2008	PLM (Power Liftgate Module)	V			V																																										
DURANGO	2008	PTS (Park Assist Module)	V			V																																										
DURANGO	2008	RADIO (Radio)	V	V		V																																										
DURANGO	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
DURANGO	2008	VES3 (Vidio Entertainment System 3)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
DURANGO	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
DURANGO	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DURANGO	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DURANGO	2007	AMP (Audio)	V	V		V																																										
DURANGO	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DURANGO	2007	DDM (Drivers Door Module)	V	V	V	V																																										
DURANGO	2007	EOM (Electric Overhead Module)	V	V	V	V																																										
DURANGO	2007	HFM (Hands Free Module)	V	V	V	V																																										
DURANGO	2007	HSM (Heated Seat Module)	V			V																																										
DURANGO	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
DURANGO	2007	MSMD (Memory Seet Module)	V	V	V	V																																										
DURANGO	2007	ORC (Occupant Restraint Control)	V	V		V																																										
DURANGO	2007	PDM (Passenger Door Module)	V	V	V	V																																										
DURANGO	2007	PLM (Power Liftgate Module)	V			V																																										
DURANGO	2007	PTS (Park Assist Module)	V			V																																										
DURANGO	2007	RADIO (Radio)	V	V		V																																										
DURANGO	2007	SAS (Steering Angle Sensor)	V	V	V	V																																										
DURANGO	2007	SDAR (Satellite Radio)	V			V																																										
DURANGO	2007	CGW (Central Gateway)	V	V	V	V																																										
DURANGO	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
DURANGO	2006	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DURANGO	2006	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DURANGO	2006	AMP (Audio)	V	V		V																																										
DURANGO	2006	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DURANGO	2006	DDM (Drivers Door Module)	V	V	V	V																																										
DURANGO	2006	EOM (Electric Overhead Module)	V	V	V	V																																										
DURANGO	2006	HFM (Hands Free Module)	V	V	V	V																																										
DURANGO	2006	HSM (Heated Seat Module)	V			V																																										
DURANGO	2006	HVAC (Heat Vent A/C)	V	V	V	V																																										
DURANGO	2006	MSMD (Memory Seet Module)	V	V	V	V																																										
DURANGO	2006	OCM (Occupant Classification Module)	V			V																																										
DURANGO	2006	ORC (Occupant Restraint Control)	V	V		V																																										
DURANGO	2006	PDM (Passenger Door Module)	V	V	V	V																																										
DURANGO	2006	PLM (Power Liftgate Module)	V			V																																										
DURANGO	2006	RADIO (Radio)	V	V		V																																										
DURANGO	2006	SAS (Steering Angle Sensor)	V	V	V	V																																										
DURANGO	2006	SDAR (Satellite Radio)	V			V																																										
DURANGO	2006	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DURANGO	2006	CGW (Central Gateway)	V	V	V	V																																										
DURANGO	2006	WCM(Wireless Control Modules)	V	V	V	V																																										
DURANGO	2005	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DURANGO	2005	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DURANGO	2005	AMP (Audio)	V	V		V																																										
DURANGO	2005	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DURANGO	2005	DDM (Drivers Door Module)	V	V	V	V																																										
DURANGO	2005	EOM (Electric Overhead Module)	V	V	V	V																																										
DURANGO	2005	HFM (Hands Free Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
DURANGO	2005	HSM (Heated Seat Module)	V			V																																										
DURANGO	2005	HVAC (Heat Vent A/C)	V	V	V	V																																										
DURANGO	2005	MSMD (Memory Seet Module)	V	V	V	V																																										
DURANGO	2005	OCM (Occupant Classification Module)	V			V																																										
DURANGO	2005	ORC (Occupant Restraint Control)	V	V		V																																										
DURANGO	2005	PDM (Passenger Door Module)	V	V	V	V																																										
DURANGO	2005	RADIO (Radio)	V	V		V																																										
DURANGO	2005	SDAR (Satellite Radio)	V			V																																										
DURANGO	2005	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DURANGO	2005	CGW (Central Gateway)	V	V	V	V																																										
DURANGO	2005	WCM(Wireless Control Modules)	V	V	V	V																																										
DURANGO	2004	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DURANGO	2004	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DURANGO	2004	AMP (Audio)	V	V		V																																										
DURANGO	2004	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DURANGO	2004	DDM (Drivers Door Module)	V	V	V	V																																										
DURANGO	2004	EOM (Electric Overhead Module)	V	V	V	V																																										
DURANGO	2004	HFM (Hands Free Module)	V	V	V	V																																										
DURANGO	2004	HSM (Heated Seat Module)	V			V																																										
DURANGO	2004	HVAC (Heat Vent A/C)	V	V	V	V																																										
DURANGO	2004	MSMD (Memory Seet Module)	V	V	V	V																																										
DURANGO	2004	OCM (Occupant Classification Module)	V			V																																										
DURANGO	2004	ORC (Occupant Restraint Control)	V	V		V																																										
DURANGO	2004	PDM (Passenger Door Module)	V	V	V	V																																										
DURANGO	2004	RADIO (Radio)	V	V		V																																										
DURANGO	2004	SDAR (Satellite Radio)	V			V																																										
DURANGO	2004	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DURANGO	2004	CGW (Central Gateway)	V	V	V	V																																										
DURANGO	2004	WCM(Wireless Control Modules)	V	V	V	V																																										
MAGNUM	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
MAGNUM	2016	ABS (Anti Lock Brake System)	V			V																																										
MAGNUM	2016	ACC (Adaptive Cruise Control)	V			V																																										
MAGNUM	2016	ADCM (Adaptive Damper Control Module)	V			V																																										
MAGNUM	2016	AFLS (Adaptive Front Light System)	V			V																																										
MAGNUM	2016	AMP (Audio)	V			V																																										
MAGNUM	2016	BCM (Body Control Module)	V			V																																										
MAGNUM	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
MAGNUM	2016	CGW (Central Gateway)	V			V																																										
MAGNUM	2016	DDM (Drivers Door Module)	V			V																																										
MAGNUM	2016	DTCM (Drive Train Control Module)	V			V																																										
MAGNUM	2016	EPS (Electric Power Steering)	V			V																																										
MAGNUM	2016	ESM (Electronic Shifter Module)	V			V																																										
MAGNUM	2016	FFCM (Front Facing Camera Module)	V	V	V	V																																										
MAGNUM	2016	HSM (Heated Seat Module)	V			V																																										
MAGNUM	2016	HVAC (Heat Vent A/C)	V			V																																										
MAGNUM	2016	ICS (Integrated Center Stack)	V			V																																										
MAGNUM	2016	IPC (Instrument Panel Cluster)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
MAGNUM	2016	ITM (Intrusion)	V			V																																										
MAGNUM	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
MAGNUM	2016	ORC (Occupant Restraint Control)	V			V																																										
MAGNUM	2016	PDM (Passenger Door Module)	V			V																																										
MAGNUM	2016	PTS (Park Assist Module)	V			V																																										
MAGNUM	2016	RADIO (Radio)	V			V																																										
MAGNUM	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
MAGNUM	2016	RFH (Radio Frequency Hub)	V			V																																										
MAGNUM	2016	SCM (Steering Column Module)	V			V																																										
MAGNUM	2016	TCM (Transmission Control Module)	V			V																																										
MAGNUM	2016	WCM(Wireless Control Modules)	V			V																																										
MAGNUM	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
MAGNUM	2015	ABS (Anti Lock Brake System)	V			V																																										
MAGNUM	2015	ACC (Adaptive Cruise Control)	V			V																																										
MAGNUM	2015	ADCM (Adaptive Damper Control Module)	V			V																																										
MAGNUM	2015	AFLS (Adaptive Front Light System)	V			V																																										
MAGNUM	2015	AMP (Audio)	V			V																																										
MAGNUM	2015	BCM (Body Control Module)	V			V																																										
MAGNUM	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
MAGNUM	2015	CGW (Central Gateway)	V			V																																										
MAGNUM	2015	DDM (Drivers Door Module)	V			V																																										
MAGNUM	2015	DTCM (Drive Train Control Module)	V			V																																										
MAGNUM	2015	EPS (Electric Power Steering)	V			V																																										
MAGNUM	2015	ESM (Electronic Shifter Module)	V			V																																										
MAGNUM	2015	FFCM (Front Facing Camera Module)	V	V	V	V																																										
MAGNUM	2015	HSM (Heated Seat Module)	V			V																																										
MAGNUM	2015	HVAC (Heat Vent A/C)	V			V																																										
MAGNUM	2015	ICS (Integrated Center Stack)	V			V																																										
MAGNUM	2015	IPC (Instrument Panel Cluster)	V			V																																										
MAGNUM	2015	ITM (Intrusion)	V			V																																										
MAGNUM	2015	LBSS (Left Blind Spot Sensor)	V			V																																										
MAGNUM	2015	ORC (Occupant Restraint Control)	V			V																																										
MAGNUM	2015	PDM (Passenger Door Module)	V			V																																										
MAGNUM	2015	PTS (Park Assist Module)	V			V																																										
MAGNUM	2015	RADIO (Radio)	V			V																																										
MAGNUM	2015	RBSS (Right Blind Spot Sensor)	V			V																																										
MAGNUM	2015	RFH (Radio Frequency Hub)	V			V																																										
MAGNUM	2015	SCM (Steering Column Module)	V			V																																										
MAGNUM	2015	TCM (Transmission Control Module)	V			V																																										
MAGNUM	2015	WCM(Wireless Control Modules)	V			V																																										
MAGNUM	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
MAGNUM	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
MAGNUM	2014	ACC (Adaptive Cruise Control)	V			V																																										
MAGNUM	2014	AMP (Audio)	V	V		V																																										
MAGNUM	2014	DDM (Drivers Door Module)	V	V	V	V																																										
MAGNUM	2014	DTCM (Drive Train Control Module)	V			V																																										
MAGNUM	2014	ESM (Electronic Shifter Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
MAGNUM	2014	HFM (Hands Free Module)	V	V	V	V																																										
MAGNUM	2014	HSM (Heated Seat Module)	V			V																																										
MAGNUM	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
MAGNUM	2014	ITM (Intrusion)	V			V																																										
MAGNUM	2014	ORC (Occupant Restraint Control)	V	V		V																																										
MAGNUM	2014	PDM (Passenger Door Module)	V	V	V	V																																										
MAGNUM	2014	PTS (Park Assist Module)	V			V																																										
MAGNUM	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
MAGNUM	2014	TPM (Tire Pressure Monitor)	V			V																																										
MAGNUM	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
MAGNUM	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
MAGNUM	2013	ACC (Adaptive Cruise Control)	V			V																																										
MAGNUM	2013	AMP (Audio)	V	V		V																																										
MAGNUM	2013	DDM (Drivers Door Module)	V	V	V	V																																										
MAGNUM	2013	DTCM (Drive Train Control Module)	V			V																																										
MAGNUM	2013	ESM (Electronic Shifter Module)	V			V																																										
MAGNUM	2013	HFM (Hands Free Module)	V	V	V	V																																										
MAGNUM	2013	HSM (Heated Seat Module)	V			V																																										
MAGNUM	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
MAGNUM	2013	ITM (Intrusion)	V			V																																										
MAGNUM	2013	ORC (Occupant Restraint Control)	V	V		V																																										
MAGNUM	2013	PDM (Passenger Door Module)	V	V	V	V																																										
MAGNUM	2013	PTS (Park Assist Module)	V			V																																										
MAGNUM	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
MAGNUM	2013	TPM (Tire Pressure Monitor)	V			V																																										
MAGNUM	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
MAGNUM	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
MAGNUM	2012	ACC (Adaptive Cruise Control)	V			V																																										
MAGNUM	2012	AMP (Audio)	V	V		V																																										
MAGNUM	2012	DDM (Drivers Door Module)	V	V	V	V																																										
MAGNUM	2012	DTCM (Drive Train Control Module)	V			V																																										
MAGNUM	2012	ESM (Electronic Shifter Module)	V			V																																										
MAGNUM	2012	HFM (Hands Free Module)	V	V	V	V																																										
MAGNUM	2012	HSM (Heated Seat Module)	V			V																																										
MAGNUM	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
MAGNUM	2012	ITM (Intrusion)	V			V																																										
MAGNUM	2012	ORC (Occupant Restraint Control)	V	V		V																																										
MAGNUM	2012	PDM (Passenger Door Module)	V	V	V	V																																										
MAGNUM	2012	PTS (Park Assist Module)	V			V																																										
MAGNUM	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
MAGNUM	2012	TPM (Tire Pressure Monitor)	V			V																																										
MAGNUM	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
MAGNUM	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
MAGNUM	2011	ACC (Adaptive Cruise Control)	V			V																																										
MAGNUM	2011	AMP (Audio)	V	V		V																																										
MAGNUM	2011	DDM (Drivers Door Module)	V	V	V	V																																										
MAGNUM	2011	DTCM (Drive Train Control Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
MAGNUM	2011	ESM (Electronic Shifter Module)	V			V																																										
MAGNUM	2011	HFM (Hands Free Module)	V	V	V	V																																										
MAGNUM	2011	HSM (Heated Seat Module)	V			V																																										
MAGNUM	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
MAGNUM	2011	ORC (Occupant Restraint Control)	V	V		V																																										
MAGNUM	2011	PDM (Passenger Door Module)	V	V	V	V																																										
MAGNUM	2011	PTS (Park Assist Module)	V			V																																										
MAGNUM	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
MAGNUM	2011	TPM (Tire Pressure Monitor)	V			V																																										
MAGNUM	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
MAGNUM	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
MAGNUM	2010	ACC (Adaptive Cruise Control)	V			V																																										
MAGNUM	2010	AHBM (Automatic High Beam)	V			V																																										
MAGNUM	2010	AMP (Audio)	V	V		V																																										
MAGNUM	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
MAGNUM	2010	DDM (Drivers Door Module)	V	V	V	V																																										
MAGNUM	2010	DTCM (Drive Train Control Module)	V			V																																										
MAGNUM	2010	EOM (Electric Overhead Module)	V	V	V	V																																										
MAGNUM	2010	ESM (Electronic Shifter Module)	V			V																																										
MAGNUM	2010	HFM (Hands Free Module)	V	V	V	V																																										
MAGNUM	2010	HSM (Heated Seat Module)	V			V																																										
MAGNUM	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
MAGNUM	2010	ITM (Intrusion)	V			V																																										
MAGNUM	2010	LRSM (Light Rain Sensor Module)	V			V																																										
MAGNUM	2010	MSMD (Memory Seet Module)	V	V	V	V																																										
MAGNUM	2010	ORC (Occupant Restraint Control)	V	V		V																																										
MAGNUM	2010	PDM (Passenger Door Module)	V	V	V	V																																										
MAGNUM	2010	PTS (Park Assist Module)	V			V																																										
MAGNUM	2010	RADIO (Radio)	V	V		V																																										
MAGNUM	2010	SCM (Steering Column Module)	V			V																																										
MAGNUM	2010	SUNR (Sunroof Module)	V			V																																										
MAGNUM	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
MAGNUM	2010	CGW (Central Gateway)	V	V	V	V																																										
MAGNUM	2010	TPM (Tire Pressure Monitor)	V			V																																										
MAGNUM	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
MAGNUM	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
MAGNUM	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
MAGNUM	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
MAGNUM	2009	ACC (Adaptive Cruise Control)	V			V																																										
MAGNUM	2009	AHBM (Automatic High Beam)	V			V																																										
MAGNUM	2009	AMP (Audio)	V	V		V																																										
MAGNUM	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
MAGNUM	2009	DDM (Drivers Door Module)	V	V	V	V																																										
MAGNUM	2009	DTCM (Drive Train Control Module)	V			V																																										
MAGNUM	2009	EOM (Electric Overhead Module)	V	V	V	V																																										
MAGNUM	2009	ESM (Electronic Shifter Module)	V			V																																										
MAGNUM	2009	HFM (Hands Free Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
MAGNUM	2009	HSM (Heated Seat Module)	V			V																																										
MAGNUM	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
MAGNUM	2009	ITM (Intrusion)	V			V																																										
MAGNUM	2009	LRSM (Light Rain Sensor Module)	V			V																																										
MAGNUM	2009	MSMD (Memory Seet Module)	V	V	V	V																																										
MAGNUM	2009	ORC (Occupant Restraint Control)	V	V		V																																										
MAGNUM	2009	PDM (Passenger Door Module)	V	V	V	V																																										
MAGNUM	2009	PTS (Park Assist Module)	V			V																																										
MAGNUM	2009	RADIO (Radio)	V	V		V																																										
MAGNUM	2009	SCM (Steering Column Module)	V			V																																										
MAGNUM	2009	SUNR (Sunroof Module)	V			V																																										
MAGNUM	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
MAGNUM	2009	CGW (Central Gateway)	V	V	V	V																																										
MAGNUM	2009	TPM (Tire Pressure Monitor)	V			V																																										
MAGNUM	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
MAGNUM	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
MAGNUM	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
MAGNUM	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
MAGNUM	2008	ACC (Adaptive Cruise Control)	V			V																																										
MAGNUM	2008	AHBM (Automatic High Beam)	V			V																																										
MAGNUM	2008	AMP (Audio)	V	V		V																																										
MAGNUM	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
MAGNUM	2008	DDM (Drivers Door Module)	V	V	V	V																																										
MAGNUM	2008	EOM (Electric Overhead Module)	V	V	V	V																																										
MAGNUM	2008	ESM (Electronic Shifter Module)	V			V																																										
MAGNUM	2008	HFM (Hands Free Module)	V	V	V	V																																										
MAGNUM	2008	HSM (Heated Seat Module)	V			V																																										
MAGNUM	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
MAGNUM	2008	ITM (Intrusion)	V			V																																										
MAGNUM	2008	LRSM (Light Rain Sensor Module)	V			V																																										
MAGNUM	2008	MSMD (Memory Seet Module)	V	V	V	V																																										
MAGNUM	2008	ORC (Occupant Restraint Control)	V	V		V																																										
MAGNUM	2008	PDM (Passenger Door Module)	V	V	V	V																																										
MAGNUM	2008	PTS (Park Assist Module)	V			V																																										
MAGNUM	2008	RADIO (Radio)	V	V		V																																										
MAGNUM	2008	SCM (Steering Column Module)	V			V																																										
MAGNUM	2008	SUNR (Sunroof Module)	V			V																																										
MAGNUM	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
MAGNUM	2008	CGW (Central Gateway)	V	V	V	V																																										
MAGNUM	2008	VES3 (Vidio Entertainment System 3)	V			V																																										
MAGNUM	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
MAGNUM	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
MAGNUM	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
MAGNUM	2007	ACC (Adaptive Cruise Control)	V			V																																										
MAGNUM	2007	AHBM (Automatic High Beam)	V			V																																										
MAGNUM	2007	AMP (Audio)	V	V		V																																										
MAGNUM	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
MAGNUM	2007	DDM (Drivers Door Module)	V	V	V	V																																										
MAGNUM	2007	EOM (Electric Overhead Module)	V	V	V	V																																										
MAGNUM	2007	ESM (Electronic Shifter Module)	V			V																																										
MAGNUM	2007	HFM (Hands Free Module)	V	V	V	V																																										
MAGNUM	2007	HSM (Heated Seat Module)	V			V																																										
MAGNUM	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
MAGNUM	2007	ITM (Intrusion)	V			V																																										
MAGNUM	2007	LRSM (Light Rain Sensor Module)	V			V																																										
MAGNUM	2007	MSMD (Memory Seet Module)	V	V	V	V																																										
MAGNUM	2007	ORC (Occupant Restraint Control)	V	V		V																																										
MAGNUM	2007	PDM (Passenger Door Module)	V	V	V	V																																										
MAGNUM	2007	PTS (Park Assist Module)	V			V																																										
MAGNUM	2007	RADIO (Radio)	V	V		V																																										
MAGNUM	2007	SCM (Steering Column Module)	V			V																																										
MAGNUM	2007	SDAR (Satellite Radio)	V			V																																										
MAGNUM	2007	SUNR (Sunroof Module)	V			V																																										
MAGNUM	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
MAGNUM	2007	CGW (Central Gateway)	V	V	V	V																																										
MAGNUM	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
MAGNUM	2006	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
MAGNUM	2006	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
MAGNUM	2006	AHBM (Automatic High Beam)	V			V																																										
MAGNUM	2006	AMP (Audio)	V	V		V																																										
MAGNUM	2006	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
MAGNUM	2006	DDM (Drivers Door Module)	V	V	V	V																																										
MAGNUM	2006	EOM (Electric Overhead Module)	V	V	V	V																																										
MAGNUM	2006	ESM (Electronic Shifter Module)	V			V																																										
MAGNUM	2006	HFM (Hands Free Module)	V	V	V	V																																										
MAGNUM	2006	HSM (Heated Seat Module)	V			V																																										
MAGNUM	2006	HVAC (Heat Vent A/C)	V	V	V	V																																										
MAGNUM	2006	ITM (Intrusion)	V			V																																										
MAGNUM	2006	LRSM (Light Rain Sensor Module)	V			V																																										
MAGNUM	2006	MSMD (Memory Seet Module)	V	V	V	V																																										
MAGNUM	2006	OCM (Occupant Classification Module)	V			V																																										
MAGNUM	2006	ORC (Occupant Restraint Control)	V	V		V																																										
MAGNUM	2006	PDM (Passenger Door Module)	V	V	V	V																																										
MAGNUM	2006	PTS (Park Assist Module)	V			V																																										
MAGNUM	2006	RADIO (Radio)	V	V		V																																										
MAGNUM	2006	SCM (Steering Column Module)	V			V																																										
MAGNUM	2006	SDAR (Satellite Radio)	V			V																																										
MAGNUM	2006	SUNR (Sunroof Module)	V			V																																										
MAGNUM	2006	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
MAGNUM	2006	CGW (Central Gateway)	V	V	V	V																																										
MAGNUM	2006	WCM(Wireless Control Modules)	V	V	V	V																																										
MAGNUM	2005	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
MAGNUM	2005	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
MAGNUM	2005	AMP (Audio)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
MAGNUM	2005	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
MAGNUM	2005	DDM (Drivers Door Module)	V	V	V	V																																										
MAGNUM	2005	EOM (Electric Overhead Module)	V	V	V	V																																										
MAGNUM	2005	ESM (Electronic Shifter Module)	V			V																																										
MAGNUM	2005	HFM (Hands Free Module)	V	V	V	V																																										
MAGNUM	2005	HSM (Heated Seat Module)	V			V																																										
MAGNUM	2005	HVAC (Heat Vent A/C)	V	V	V	V																																										
MAGNUM	2005	LRSM (Light Rain Sensor Module)	V			V																																										
MAGNUM	2005	MSMD (Memory Seet Module)	V	V	V	V																																										
MAGNUM	2005	OCM (Occupant Classification Module)	V			V																																										
MAGNUM	2005	ORC (Occupant Restraint Control)	V	V		V																																										
MAGNUM	2005	PDM (Passenger Door Module)	V	V	V	V																																										
MAGNUM	2005	PTS (Park Assist Module)	V			V																																										
MAGNUM	2005	RADIO (Radio)	V	V		V																																										
MAGNUM	2005	SCM (Steering Column Module)	V			V																																										
MAGNUM	2005	SDAR (Satellite Radio)	V			V																																										
MAGNUM	2005	SUNR (Sunroof Module)	V			V																																										
MAGNUM	2005	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
MAGNUM	2005	CGW (Central Gateway)	V	V	V	V																																										
MAGNUM	2005	WCM(Wireless Control Modules)	V	V	V	V																																										
CHARGER	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHARGER	2016	ABS (Anti Lock Brake System)	V			V																																										
CHARGER	2016	ACC (Adaptive Cruise Control)	V			V																																										
CHARGER	2016	ADCM (Adaptive Damper Control Module)	V			V																																										
CHARGER	2016	AFLS (Adaptive Front Light System)	V			V																																										
CHARGER	2016	AMP (Audio)	V			V																																										
CHARGER	2016	BCM (Body Control Module)	V			V																																										
CHARGER	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
CHARGER	2016	CGW (Central Gateway)	V			V																																										
CHARGER	2016	DDM (Drivers Door Module)	V			V																																										
CHARGER	2016	DTCM (Drive Train Control Module)	V			V																																										
CHARGER	2016	EPS (Electric Power Steering)	V			V																																										
CHARGER	2016	ESM (Electronic Shifter Module)	V			V																																										
CHARGER	2016	FFCM (Front Facing Camera Module)	V	V	V	V																																										
CHARGER	2016	HSM (Heated Seat Module)	V			V																																										
CHARGER	2016	HVAC (Heat Vent A/C)	V			V																																										
CHARGER	2016	ICS (Integrated Center Stack)	V			V																																										
CHARGER	2016	IPC (Instrument Panel Cluster)	V			V																																										
CHARGER	2016	ITM (Intrusion)	V			V																																										
CHARGER	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
CHARGER	2016	ORC (Occupant Restraint Control)	V			V																																										
CHARGER	2016	PDM (Passenger Door Module)	V			V																																										
CHARGER	2016	PTS (Park Assist Module)	V			V																																										
CHARGER	2016	RADIO (Radio)	V			V																																										
CHARGER	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
CHARGER	2016	RFH (Radio Frequency Hub)	V			V																																										
CHARGER	2016	SCM (Steering Column Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CHARGER	2016	TCM (Transmission Control Module)	V			V																																									
CHARGER	2016	WCM(Wireless Control Modules)	V			V																																									
CHARGER	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
CHARGER	2015	ABS (Anti Lock Brake System)	V			V																																									
CHARGER	2015	ACC (Adaptive Cruise Control)	V			V																																									
CHARGER	2015	ADCM (Adaptive Damper Control Module)	V			V																																									
CHARGER	2015	AFLS (Adaptive Front Light System)	V			V																																									
CHARGER	2015	AMP (Audio)	V			V																																									
CHARGER	2015	BCM (Body Control Module)	V			V																																									
CHARGER	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																									
CHARGER	2015	CGW (Central Gateway)	V			V																																									
CHARGER	2015	DDM (Drivers Door Module)	V			V																																									
CHARGER	2015	DTCM (Drive Train Control Module)	V			V																																									
CHARGER	2015	EPS (Electric Power Steering)	V			V																																									
CHARGER	2015	ESM (Electronic Shifter Module)	V			V																																									
CHARGER	2015	FFCM (Front Facing Camera Module)	V	V	V	V																																									
CHARGER	2015	HSM (Heated Seat Module)	V			V																																									
CHARGER	2015	HVAC (Heat Vent A/C)	V			V																																									
CHARGER	2015	ICS (Integrated Center Stack)	V			V																																									
CHARGER	2015	IPC (Instrument Panel Cluster)	V			V																																									
CHARGER	2015	ITM (Intrusion)	V			V																																									
CHARGER	2015	LBSS (Left Blind Spot Sensor)	V			V																																									
CHARGER	2015	ORC (Occupant Restraint Control)	V			V																																									
CHARGER	2015	PDM (Passenger Door Module)	V			V																																									
CHARGER	2015	PTS (Park Assist Module)	V			V																																									
CHARGER	2015	RADIO (Radio)	V			V																																									
CHARGER	2015	RBSS (Right Blind Spot Sensor)	V			V																																									
CHARGER	2015	RFH (Radio Frequency Hub)	V			V																																									
CHARGER	2015	SCM (Steering Column Module)	V			V																																									
CHARGER	2015	TCM (Transmission Control Module)	V			V																																									
CHARGER	2015	WCM(Wireless Control Modules)	V			V																																									
CHARGER	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
CHARGER	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
CHARGER	2014	ACC (Adaptive Cruise Control)	V			V																																									
CHARGER	2014	AMP (Audio)	V	V		V																																									
CHARGER	2014	DDM (Drivers Door Module)	V	V	V	V																																									
CHARGER	2014	DTCM (Drive Train Control Module)	V			V																																									
CHARGER	2014	ESM (Electronic Shifter Module)	V			V																																									
CHARGER	2014	HFM (Hands Free Module)	V	V	V	V																																									
CHARGER	2014	HSM (Heated Seat Module)	V			V																																									
CHARGER	2014	HVAC (Heat Vent A/C)	V	V	V	V																																									
CHARGER	2014	ITM (Intrusion)	V			V																																									
CHARGER	2014	ORC (Occupant Restraint Control)	V	V		V																																									
CHARGER	2014	PDM (Passenger Door Module)	V	V	V	V																																									
CHARGER	2014	PTS (Park Assist Module)	V			V																																									
CHARGER	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHARGER	2014	TPM (Tire Pressure Monitor)	V			V																																									

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CHARGER	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHARGER	2013	ABS (Anti Lock Brake System)	V	V	V	V				V																																			V	V	V	V
CHARGER	2013	ACC (Adaptive Cruise Control)	V			V																																										
CHARGER	2013	AMP (Audio)	V	V		V																																										
CHARGER	2013	DDM (Drivers Door Module)	V	V	V	V																																										
CHARGER	2013	DTCM (Drive Train Control Module)	V			V																																										
CHARGER	2013	ESM (Electronic Shifter Module)	V			V																																										
CHARGER	2013	HFM (Hands Free Module)	V	V	V	V																																										
CHARGER	2013	HSM (Heated Seat Module)	V			V																																										
CHARGER	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHARGER	2013	ITM (Intrusion)	V			V																																										
CHARGER	2013	ORC (Occupant Restraint Control)	V	V		V																																										
CHARGER	2013	PDM (Passenger Door Module)	V	V	V	V																																										
CHARGER	2013	PTS (Park Assist Module)	V			V																																										
CHARGER	2013	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
CHARGER	2013	TPM (Tire Pressure Monitor)	V			V																																										
CHARGER	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHARGER	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CHARGER	2012	ACC (Adaptive Cruise Control)	V			V																																										
CHARGER	2012	AMP (Audio)	V	V		V																																										
CHARGER	2012	DDM (Drivers Door Module)	V	V	V	V																																										
CHARGER	2012	DTCM (Drive Train Control Module)	V			V																																										
CHARGER	2012	ESM (Electronic Shifter Module)	V			V																																										
CHARGER	2012	HFM (Hands Free Module)	V	V	V	V																																										
CHARGER	2012	HSM (Heated Seat Module)	V			V																																										
CHARGER	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHARGER	2012	ITM (Intrusion)	V			V																																										
CHARGER	2012	ORC (Occupant Restraint Control)	V	V		V																																										
CHARGER	2012	PDM (Passenger Door Module)	V	V	V	V																																										
CHARGER	2012	PTS (Park Assist Module)	V			V																																										
CHARGER	2012	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
CHARGER	2012	TPM (Tire Pressure Monitor)	V			V																																										
CHARGER	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHARGER	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CHARGER	2011	ACC (Adaptive Cruise Control)	V			V																																										
CHARGER	2011	AMP (Audio)	V	V		V																																										
CHARGER	2011	DDM (Drivers Door Module)	V	V	V	V																																										
CHARGER	2011	DTCM (Drive Train Control Module)	V			V																																										
CHARGER	2011	ESM (Electronic Shifter Module)	V			V																																										
CHARGER	2011	HFM (Hands Free Module)	V	V	V	V																																										
CHARGER	2011	HSM (Heated Seat Module)	V			V																																										
CHARGER	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHARGER	2011	ORC (Occupant Restraint Control)	V	V		V																																										
CHARGER	2011	PDM (Passenger Door Module)	V	V	V	V																																										
CHARGER	2011	PTS (Park Assist Module)	V			V																																										
CHARGER	2011	TCM (Transmission Control Module)	V	V	V	V	V																																	V	V	V	V	V	V				
CHARGER	2011	TPM (Tire Pressure Monitor)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CHARGER	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
CHARGER	2010	ABS (Anti Lock Brake System)	V	V	V	V				V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
CHARGER	2010	ACC (Adaptive Cruise Control)	V			V																																										
CHARGER	2010	AHBM (Automatic High Beam)	V			V																																										
CHARGER	2010	AMP (Audio)	V	V		V																																										
CHARGER	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHARGER	2010	DDM (Drivers Door Module)	V	V	V	V																																										
CHARGER	2010	DTCM (Drive Train Control Module)	V			V																																										
CHARGER	2010	EOM (Electric Overhead Module)	V	V	V	V																																										
CHARGER	2010	ESM (Electronic Shifter Module)	V			V																																										
CHARGER	2010	HFM (Hands Free Module)	V	V	V	V																																										
CHARGER	2010	HSM (Heated Seat Module)	V			V																																										
CHARGER	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHARGER	2010	ITM (Intrusion)	V			V																																										
CHARGER	2010	LRSM (Light Rain Sensor Module)	V			V																																										
CHARGER	2010	MSMD (Memory Seet Module)	V	V	V	V																																										
CHARGER	2010	ORC (Occupant Restraint Control)	V	V		V																																										
CHARGER	2010	PDM (Passenger Door Module)	V	V	V	V																																										
CHARGER	2010	PTS (Park Assist Module)	V			V																																										
CHARGER	2010	RADIO (Radio)	V	V		V																																										
CHARGER	2010	SCM (Steering Column Module)	V			V																																										
CHARGER	2010	SUNR (Sunroof Module)	V			V																																										
CHARGER	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHARGER	2010	CGW (Central Gateway)	V	V	V	V																																										
CHARGER	2010	TPM (Tire Pressure Monitor)	V			V																																										
CHARGER	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
CHARGER	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
CHARGER	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
CHARGER	2009	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
CHARGER	2009	ACC (Adaptive Cruise Control)	V			V																																										
CHARGER	2009	AHBM (Automatic High Beam)	V			V																																										
CHARGER	2009	AMP (Audio)	V	V		V																																										
CHARGER	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHARGER	2009	DDM (Drivers Door Module)	V	V	V	V																																										
CHARGER	2009	DTCM (Drive Train Control Module)	V			V																																										
CHARGER	2009	EOM (Electric Overhead Module)	V	V	V	V																																										
CHARGER	2009	ESM (Electronic Shifter Module)	V			V																																										
CHARGER	2009	HFM (Hands Free Module)	V	V	V	V																																										
CHARGER	2009	HSM (Heated Seat Module)	V			V																																										
CHARGER	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHARGER	2009	ITM (Intrusion)	V			V																																										
CHARGER	2009	LRSM (Light Rain Sensor Module)	V			V																																										
CHARGER	2009	MSMD (Memory Seet Module)	V	V	V	V																																										
CHARGER	2009	ORC (Occupant Restraint Control)	V	V		V																																										
CHARGER	2009	PDM (Passenger Door Module)	V	V	V	V																																										
CHARGER	2009	PTS (Park Assist Module)	V			V																																										
CHARGER	2009	RADIO (Radio)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CHARGER	2009	SCM (Steering Column Module)	V			V																																										
CHARGER	2009	SUNR (Sunroof Module)	V			V																																										
CHARGER	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHARGER	2009	CGW (Central Gateway)	V	V	V	V																																										
CHARGER	2009	TPM (Tire Pressure Monitor)	V			V																																										
CHARGER	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
CHARGER	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
CHARGER	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHARGER	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CHARGER	2008	ACC (Adaptive Cruise Control)	V			V																																										
CHARGER	2008	AHBM (Automatic High Beam)	V			V																																										
CHARGER	2008	AMP (Audio)	V	V		V																																										
CHARGER	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHARGER	2008	DDM (Drivers Door Module)	V	V	V	V																																										
CHARGER	2008	EOM (Electric Overhead Module)	V	V	V	V																																										
CHARGER	2008	ESM (Electronic Shifter Module)	V			V																																										
CHARGER	2008	HFM (Hands Free Module)	V	V	V	V																																										
CHARGER	2008	HSM (Heated Seat Module)	V			V																																										
CHARGER	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHARGER	2008	ITM (Intrusion)	V			V																																										
CHARGER	2008	LRSM (Light Rain Sensor Module)	V			V																																										
CHARGER	2008	MSMD (Memory Seet Module)	V	V	V	V																																										
CHARGER	2008	ORC (Occupant Restraint Control)	V	V		V																																										
CHARGER	2008	PDM (Passenger Door Module)	V	V	V	V																																										
CHARGER	2008	PTS (Park Assist Module)	V			V																																										
CHARGER	2008	RADIO (Radio)	V	V		V																																										
CHARGER	2008	SCM (Steering Column Module)	V			V																																										
CHARGER	2008	SUNR (Sunroof Module)	V			V																																										
CHARGER	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHARGER	2008	CGW (Central Gateway)	V	V	V	V																																										
CHARGER	2008	VES3 (Vidio Entertainment System 3)	V			V																																										
CHARGER	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
CHARGER	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHARGER	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CHARGER	2007	ACC (Adaptive Cruise Control)	V			V																																										
CHARGER	2007	AHBM (Automatic High Beam)	V			V																																										
CHARGER	2007	AMP (Audio)	V	V		V																																										
CHARGER	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHARGER	2007	DDM (Drivers Door Module)	V	V	V	V																																										
CHARGER	2007	EOM (Electric Overhead Module)	V	V	V	V																																										
CHARGER	2007	ESM (Electronic Shifter Module)	V			V																																										
CHARGER	2007	HFM (Hands Free Module)	V	V	V	V																																										
CHARGER	2007	HSM (Heated Seat Module)	V			V																																										
CHARGER	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHARGER	2007	ITM (Intrusion)	V			V																																										
CHARGER	2007	LRSM (Light Rain Sensor Module)	V			V																																										
CHARGER	2007	MSMD (Memory Seet Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CHARGER	2007	ORC (Occupant Restraint Control)	V	V		V																																										
CHARGER	2007	PDM (Passenger Door Module)	V	V	V	V																																										
CHARGER	2007	PTS (Park Assist Module)	V			V																																										
CHARGER	2007	RADIO (Radio)	V	V		V																																										
CHARGER	2007	SCM (Steering Column Module)	V			V																																										
CHARGER	2007	SDAR (Satellite Radio)	V			V																																										
CHARGER	2007	SUNR (Sunroof Module)	V			V																																										
CHARGER	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHARGER	2007	CGW (Central Gateway)	V	V	V	V																																										
CHARGER	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
CHARGER	2006	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHARGER	2006	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CHARGER	2006	AHBM (Automatic High Beam)	V			V																																										
CHARGER	2006	AMP (Audio)	V	V		V																																										
CHARGER	2006	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHARGER	2006	DDM (Drivers Door Module)	V	V	V	V																																										
CHARGER	2006	EOM (Electric Overhead Module)	V	V	V	V																																										
CHARGER	2006	ESM (Electronic Shifter Module)	V			V																																										
CHARGER	2006	HFM (Hands Free Module)	V	V	V	V																																										
CHARGER	2006	HSM (Heated Seat Module)	V			V																																										
CHARGER	2006	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHARGER	2006	ITM (Intrusion)	V			V																																										
CHARGER	2006	LRSM (Light Rain Sensor Module)	V			V																																										
CHARGER	2006	MSMD (Memory Seet Module)	V	V	V	V																																										
CHARGER	2006	OCM (Occupant Classification Module)	V			V																																										
CHARGER	2006	ORC (Occupant Restraint Control)	V	V		V																																										
CHARGER	2006	PDM (Passenger Door Module)	V	V	V	V																																										
CHARGER	2006	PTS (Park Assist Module)	V			V																																										
CHARGER	2006	RADIO (Radio)	V	V		V																																										
CHARGER	2006	SCM (Steering Column Module)	V			V																																										
CHARGER	2006	SDAR (Satellite Radio)	V			V																																										
CHARGER	2006	SUNR (Sunroof Module)	V			V																																										
CHARGER	2006	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHARGER	2006	CGW (Central Gateway)	V	V	V	V																																										
CHARGER	2006	WCM(Wireless Control Modules)	V	V	V	V																																										
CHARGER	2005	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHARGER	2005	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CHARGER	2005	AMP (Audio)	V	V		V																																										
CHARGER	2005	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHARGER	2005	DDM (Drivers Door Module)	V	V	V	V																																										
CHARGER	2005	EOM (Electric Overhead Module)	V	V	V	V																																										
CHARGER	2005	ESM (Electronic Shifter Module)	V			V																																										
CHARGER	2005	HFM (Hands Free Module)	V	V	V	V																																										
CHARGER	2005	HSM (Heated Seat Module)	V			V																																										
CHARGER	2005	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHARGER	2005	LRSM (Light Rain Sensor Module)	V			V																																										
CHARGER	2005	MSMD (Memory Seet Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CHARGER	2005	OCM (Occupant Classification Module)	V			V																																										
CHARGER	2005	ORC (Occupant Restraint Control)	V	V		V																																										
CHARGER	2005	PDM (Passenger Door Module)	V	V	V	V																																										
CHARGER	2005	PTS (Park Assist Module)	V			V																																										
CHARGER	2005	RADIO (Radio)	V	V		V																																										
CHARGER	2005	SCM (Steering Column Module)	V			V																																										
CHARGER	2005	SDAR (Satellite Radio)	V			V																																										
CHARGER	2005	SUNR (Sunroof Module)	V			V																																										
CHARGER	2005	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHARGER	2005	CGW (Central Gateway)	V	V	V	V																																										
CHARGER	2005	WCM(Wireless Control Modules)	V	V	V	V																																										
DAKOTA	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
DAKOTA	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DAKOTA	2012	AMP (Audio)	V	V		V																																										
DAKOTA	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DAKOTA	2012	EOM (Electric Overhead Module)	V	V	V	V																																										
DAKOTA	2012	HFM (Hands Free Module)	V	V	V	V																																										
DAKOTA	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
DAKOTA	2012	ORC (Occupant Restraint Control)	V	V		V																																										
DAKOTA	2012	RADIO (Radio)	V	V		V																																										
DAKOTA	2012	CGW (Central Gateway)	V	V	V	V																																										
DAKOTA	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
DAKOTA	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
DAKOTA	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DAKOTA	2011	AMP (Audio)	V	V		V																																										
DAKOTA	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DAKOTA	2011	EOM (Electric Overhead Module)	V	V	V	V																																										
DAKOTA	2011	HFM (Hands Free Module)	V	V	V	V																																										
DAKOTA	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
DAKOTA	2011	ORC (Occupant Restraint Control)	V	V		V																																										
DAKOTA	2011	RADIO (Radio)	V	V		V																																										
DAKOTA	2011	CGW (Central Gateway)	V	V	V	V																																										
DAKOTA	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
DAKOTA	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
DAKOTA	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DAKOTA	2010	AMP (Audio)	V	V		V																																										
DAKOTA	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DAKOTA	2010	EOM (Electric Overhead Module)	V	V	V	V																																										
DAKOTA	2010	HFM (Hands Free Module)	V	V	V	V																																										
DAKOTA	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
DAKOTA	2010	ORC (Occupant Restraint Control)	V	V		V																																										
DAKOTA	2010	RADIO (Radio)	V	V		V																																										
DAKOTA	2010	CGW (Central Gateway)	V	V	V	V																																										
DAKOTA	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
DAKOTA	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
DAKOTA	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
DAKOTA	2009	AMP (Audio)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
DAKOTA	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DAKOTA	2009	EOM (Electric Overhead Module)	V	V	V	V																																										
DAKOTA	2009	HFM (Hands Free Module)	V	V	V	V																																										
DAKOTA	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
DAKOTA	2009	ORC (Occupant Restraint Control)	V	V		V																																										
DAKOTA	2009	RADIO (Radio)	V	V		V																																										
DAKOTA	2009	CGW (Central Gateway)	V	V	V	V																																										
DAKOTA	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
DAKOTA	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
DAKOTA	2008	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
DAKOTA	2008	AMP (Audio)	V	V		V																																										
DAKOTA	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DAKOTA	2008	EOM (Electric Overhead Module)	V	V	V	V																																										
DAKOTA	2008	HFM (Hands Free Module)	V	V	V	V																																										
DAKOTA	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
DAKOTA	2008	ORC (Occupant Restraint Control)	V	V		V																																										
DAKOTA	2008	RADIO (Radio)	V	V		V																																										
DAKOTA	2008	CGW (Central Gateway)	V	V	V	V																																										
DAKOTA	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
DAKOTA	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
DAKOTA	2007	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
DAKOTA	2007	AMP (Audio)	V	V		V																																										
DAKOTA	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DAKOTA	2007	EOM (Electric Overhead Module)	V	V	V	V																																										
DAKOTA	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
DAKOTA	2007	OCM (Occupant Classification Module)	V			V																																										
DAKOTA	2007	ORC (Occupant Restraint Control)	V	V		V																																										
DAKOTA	2007	RADIO (Radio)	V	V		V																																										
DAKOTA	2007	SDAR (Satellite Radio)	V			V																																										
DAKOTA	2007	CGW (Central Gateway)	V	V	V	V																																										
DAKOTA	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
DAKOTA	2006	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
DAKOTA	2006	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
DAKOTA	2006	AMP (Audio)	V	V		V																																										
DAKOTA	2006	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DAKOTA	2006	EOM (Electric Overhead Module)	V	V	V	V																																										
DAKOTA	2006	HFM (Hands Free Module)	V	V	V	V																																										
DAKOTA	2006	HVAC (Heat Vent A/C)	V	V	V	V																																										
DAKOTA	2006	OCM (Occupant Classification Module)	V			V																																										
DAKOTA	2006	ORC (Occupant Restraint Control)	V	V		V																																										
DAKOTA	2006	RADIO (Radio)	V	V		V																																										
DAKOTA	2006	SDAR (Satellite Radio)	V			V																																										
DAKOTA	2006	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DAKOTA	2006	CGW (Central Gateway)	V	V	V	V																																										
DAKOTA	2006	WCM(Wireless Control Modules)	V	V	V	V																																										
DAKOTA	2005	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
DAKOTA	2005	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
DAKOTA	2005	AMP (Audio)	V	V		V																																										
DAKOTA	2005	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DAKOTA	2005	EOM (Electric Overhead Module)	V	V	V	V																																										
DAKOTA	2005	HFM (Hands Free Module)	V	V	V	V																																										
DAKOTA	2005	HVAC (Heat Vent A/C)	V	V	V	V																																										
DAKOTA	2005	OCM (Occupant Classification Module)	V			V																																										
DAKOTA	2005	ORC (Occupant Restraint Control)	V	V		V																																										
DAKOTA	2005	RADIO (Radio)	V	V		V																																										
DAKOTA	2005	SDAR (Satellite Radio)	V			V																																										
DAKOTA	2005	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DAKOTA	2005	CGW (Central Gateway)	V	V	V	V																																										
DAKOTA	2005	WCM(Wireless Control Modules)	V	V	V	V																																										
AVENGER	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
AVENGER	2014	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
AVENGER	2014	AMP (Audio)	V	V		V																																										
AVENGER	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
AVENGER	2014	DDM (Drivers Door Module)	V	V	V	V																																										
AVENGER	2014	HFM (Hands Free Module)	V	V	V	V																																										
AVENGER	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
AVENGER	2014	ORC (Occupant Restraint Control)	V	V		V																																										
AVENGER	2014	PDM (Passenger Door Module)	V	V	V	V																																										
AVENGER	2014	RADIO (Radio)	V	V		V																																										
AVENGER	2014	SAS (Steering Angle Sensor)	V	V	V	V																																										
AVENGER	2014	CGW (Central Gateway)	V	V	V	V																																										
AVENGER	2014	WCM(Wireless Control Modules)	V	V	V	V																																										
AVENGER	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
AVENGER	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
AVENGER	2013	AMP (Audio)	V	V		V																																										
AVENGER	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
AVENGER	2013	DDM (Drivers Door Module)	V	V	V	V																																										
AVENGER	2013	HFM (Hands Free Module)	V	V	V	V																																										
AVENGER	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
AVENGER	2013	ORC (Occupant Restraint Control)	V	V		V																																										
AVENGER	2013	PDM (Passenger Door Module)	V	V	V	V																																										
AVENGER	2013	RADIO (Radio)	V	V		V																																										
AVENGER	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
AVENGER	2013	CGW (Central Gateway)	V	V	V	V																																										
AVENGER	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
AVENGER	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
AVENGER	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
AVENGER	2012	AMP (Audio)	V	V		V																																										
AVENGER	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
AVENGER	2012	DDM (Drivers Door Module)	V	V	V	V																																										
AVENGER	2012	HFM (Hands Free Module)	V	V	V	V																																										
AVENGER	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
AVENGER	2012	ORC (Occupant Restraint Control)	V	V		V																																										
AVENGER	2012	PDM (Passenger Door Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
AVENGER	2012	RADIO (Radio)	V	V		V																																										
AVENGER	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
AVENGER	2012	CGW (Central Gateway)	V	V	V	V																																										
AVENGER	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
AVENGER	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
AVENGER	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
AVENGER	2011	AMP (Audio)	V	V		V																																										
AVENGER	2011	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
AVENGER	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
AVENGER	2011	DDM (Drivers Door Module)	V	V	V	V																																										
AVENGER	2011	ESM (Electronic Shifter Module)	V			V																																										
AVENGER	2011	HFM (Hands Free Module)	V	V	V	V																																										
AVENGER	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
AVENGER	2011	ITM (Intrusion)	V			V																																										
AVENGER	2011	ORC (Occupant Restraint Control)	V	V		V																																										
AVENGER	2011	PDM (Passenger Door Module)	V	V	V	V																																										
AVENGER	2011	RADIO (Radio)	V	V		V																																										
AVENGER	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
AVENGER	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
AVENGER	2011	CGW (Central Gateway)	V	V	V	V																																										
AVENGER	2011	VES3 (Vidio Entertainment System 3)	V			V																																										
AVENGER	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
AVENGER	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
AVENGER	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
AVENGER	2010	AMP (Audio)	V	V		V																																										
AVENGER	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
AVENGER	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
AVENGER	2010	DDM (Drivers Door Module)	V	V	V	V																																										
AVENGER	2010	HFM (Hands Free Module)	V	V	V	V																																										
AVENGER	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
AVENGER	2010	ITM (Intrusion)	V			V																																										
AVENGER	2010	ORC (Occupant Restraint Control)	V	V		V																																										
AVENGER	2010	PDM (Passenger Door Module)	V	V	V	V																																										
AVENGER	2010	RADIO (Radio)	V	V		V																																										
AVENGER	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
AVENGER	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
AVENGER	2010	CGW (Central Gateway)	V	V	V	V																																										
AVENGER	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
AVENGER	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
AVENGER	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
AVENGER	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
AVENGER	2009	AMP (Audio)	V	V		V																																										
AVENGER	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
AVENGER	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
AVENGER	2009	DDM (Drivers Door Module)	V	V	V	V																																										
AVENGER	2009	HFM (Hands Free Module)	V	V	V	V																																										
AVENGER	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
AVENGER	2009	ITM (Intrusion)	V			V																																										
AVENGER	2009	ORC (Occupant Restraint Control)	V	V		V																																										
AVENGER	2009	PDM (Passenger Door Module)	V	V	V	V																																										
AVENGER	2009	RADIO (Radio)	V	V		V																																										
AVENGER	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
AVENGER	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
AVENGER	2009	CGW (Central Gateway)	V	V	V	V																																										
AVENGER	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
AVENGER	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
AVENGER	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
AVENGER	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
AVENGER	2008	AMP (Audio)	V	V		V																																										
AVENGER	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
AVENGER	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
AVENGER	2008	DDM (Drivers Door Module)	V	V	V	V																																										
AVENGER	2008	HFM (Hands Free Module)	V	V	V	V																																										
AVENGER	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
AVENGER	2008	ITM (Intrusion)	V			V																																										
AVENGER	2008	ORC (Occupant Restraint Control)	V	V		V																																										
AVENGER	2008	PDM (Passenger Door Module)	V	V	V	V																																										
AVENGER	2008	RADIO (Radio)	V	V		V																																										
AVENGER	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
AVENGER	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
AVENGER	2008	CGW (Central Gateway)	V	V	V	V																																										
AVENGER	2008	VES3 (Vidio Entertainment System 3)	V			V																																										
AVENGER	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
AVENGER	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
AVENGER	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
AVENGER	2007	AMP (Audio)	V	V		V																																										
AVENGER	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
AVENGER	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
AVENGER	2007	DDM (Drivers Door Module)	V	V	V	V																																										
AVENGER	2007	HFM (Hands Free Module)	V	V	V	V																																										
AVENGER	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
AVENGER	2007	ITM (Intrusion)	V			V																																										
AVENGER	2007	ORC (Occupant Restraint Control)	V	V		V																																										
AVENGER	2007	PDM (Passenger Door Module)	V	V	V	V																																										
AVENGER	2007	RADIO (Radio)	V	V		V																																										
AVENGER	2007	SAS (Steering Angle Sensor)	V	V	V	V																																										
AVENGER	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
AVENGER	2007	CGW (Central Gateway)	V	V	V	V																																										
AVENGER	2007	VES3 (Vidio Entertainment System 3)	V			V																																										
AVENGER	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
NITRO	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
NITRO	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
NITRO	2012	AMP (Audio)	V	V		V																																										
NITRO	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
NITRO	2012	ESM (Electronic Shifter Module)	V			V																																										
NITRO	2012	HFM (Hands Free Module)	V	V	V	V																																										
NITRO	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
NITRO	2012	ITM (Intrusion)	V			V																																										
NITRO	2012	OCM (Occupant Classification Module)	V			V																																										
NITRO	2012	ORC (Occupant Restraint Control)	V	V		V																																										
NITRO	2012	PTS (Park Assist Module)	V			V																																										
NITRO	2012	RADIO (Radio)	V	V		V																																										
NITRO	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
NITRO	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
NITRO	2012	CGW (Central Gateway)	V	V	V	V																																										
NITRO	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
NITRO	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
NITRO	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
NITRO	2011	AMP (Audio)	V	V		V																																										
NITRO	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
NITRO	2011	ESM (Electronic Shifter Module)	V			V																																										
NITRO	2011	HFM (Hands Free Module)	V	V	V	V																																										
NITRO	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
NITRO	2011	ITM (Intrusion)	V			V																																										
NITRO	2011	OCM (Occupant Classification Module)	V			V																																										
NITRO	2011	ORC (Occupant Restraint Control)	V	V		V																																										
NITRO	2011	PTS (Park Assist Module)	V			V																																										
NITRO	2011	RADIO (Radio)	V	V		V																																										
NITRO	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
NITRO	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
NITRO	2011	CGW (Central Gateway)	V	V	V	V																																										
NITRO	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
NITRO	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
NITRO	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
NITRO	2010	AMP (Audio)	V	V		V																																										
NITRO	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
NITRO	2010	ESM (Electronic Shifter Module)	V			V																																										
NITRO	2010	HFM (Hands Free Module)	V	V	V	V																																										
NITRO	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
NITRO	2010	ITM (Intrusion)	V			V																																										
NITRO	2010	OCM (Occupant Classification Module)	V			V																																										
NITRO	2010	ORC (Occupant Restraint Control)	V	V		V																																										
NITRO	2010	PTS (Park Assist Module)	V			V																																										
NITRO	2010	RADIO (Radio)	V	V		V																																										
NITRO	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
NITRO	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
NITRO	2010	CGW (Central Gateway)	V	V	V	V																																										
NITRO	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
NITRO	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
NITRO	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
NITRO	2009	AMP (Audio)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
NITRO	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
NITRO	2009	ESM (Electronic Shifter Module)	V			V																																										
NITRO	2009	HFM (Hands Free Module)	V	V	V	V																																										
NITRO	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
NITRO	2009	ITM (Intrusion)	V			V																																										
NITRO	2009	OCM (Occupant Classification Module)	V			V																																										
NITRO	2009	ORC (Occupant Restraint Control)	V	V		V																																										
NITRO	2009	PTS (Park Assist Module)	V			V																																										
NITRO	2009	RADIO (Radio)	V	V		V																																										
NITRO	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
NITRO	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
NITRO	2009	CGW (Central Gateway)	V	V	V	V																																										
NITRO	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
NITRO	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
NITRO	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
NITRO	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
NITRO	2008	AMP (Audio)	V	V		V																																										
NITRO	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
NITRO	2008	ESM (Electronic Shifter Module)	V			V																																										
NITRO	2008	HFM (Hands Free Module)	V	V	V	V																																										
NITRO	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
NITRO	2008	ITM (Intrusion)	V			V																																										
NITRO	2008	OCM (Occupant Classification Module)	V			V																																										
NITRO	2008	ORC (Occupant Restraint Control)	V	V		V																																										
NITRO	2008	PTS (Park Assist Module)	V			V																																										
NITRO	2008	RADIO (Radio)	V	V		V																																										
NITRO	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
NITRO	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
NITRO	2008	CGW (Central Gateway)	V	V	V	V																																										
NITRO	2008	VES3 (Vidio Entertainment System 3)	V			V																																										
NITRO	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
NITRO	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
NITRO	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
NITRO	2007	AMP (Audio)	V	V		V																																										
NITRO	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
NITRO	2007	ESM (Electronic Shifter Module)	V			V																																										
NITRO	2007	HFM (Hands Free Module)	V	V	V	V																																										
NITRO	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
NITRO	2007	ITM (Intrusion)	V			V																																										
NITRO	2007	OCM (Occupant Classification Module)	V			V																																										
NITRO	2007	ORC (Occupant Restraint Control)	V	V		V																																										
NITRO	2007	PTS (Park Assist Module)	V			V																																										
NITRO	2007	RADIO (Radio)	V	V		V																																										
NITRO	2007	SAS (Steering Angle Sensor)	V	V	V	V																																										
NITRO	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
NITRO	2007	CGW (Central Gateway)	V	V	V	V																																										
NITRO	2007	VES3 (Vidio Entertainment System 3)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
NITRO	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
CLIBER	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CLIBER	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CLIBER	2012	AMP (Audio)	V	V		V																																										
CLIBER	2012	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
CLIBER	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CLIBER	2012	HFM (Hands Free Module)	V	V	V	V																																										
CLIBER	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
CLIBER	2012	ITM (Intrusion)	V			V																																										
CLIBER	2012	ORC (Occupant Restraint Control)	V	V		V																																										
CLIBER	2012	RADIO (Radio)	V	V		V																																										
CLIBER	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
CLIBER	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CLIBER	2012	CGW (Central Gateway)	V	V	V	V																																										
CLIBER	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
CLIBER	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CLIBER	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CLIBER	2011	AMP (Audio)	V	V		V																																										
CLIBER	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CLIBER	2011	HFM (Hands Free Module)	V	V	V	V																																										
CLIBER	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
CLIBER	2011	ITM (Intrusion)	V			V																																										
CLIBER	2011	ORC (Occupant Restraint Control)	V	V		V																																										
CLIBER	2011	RADIO (Radio)	V	V		V																																										
CLIBER	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
CLIBER	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CLIBER	2011	CGW (Central Gateway)	V	V	V	V																																										
CLIBER	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
CLIBER	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CLIBER	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CLIBER	2010	AMP (Audio)	V	V		V																																										
CLIBER	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
CLIBER	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CLIBER	2010	HFM (Hands Free Module)	V	V	V	V																																										
CLIBER	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
CLIBER	2010	ITM (Intrusion)	V			V																																										
CLIBER	2010	ORC (Occupant Restraint Control)	V	V		V																																										
CLIBER	2010	RADIO (Radio)	V	V		V																																										
CLIBER	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
CLIBER	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CLIBER	2010	CGW (Central Gateway)	V	V	V	V																																										
CLIBER	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
CLIBER	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CLIBER	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CLIBER	2009	AMP (Audio)	V	V		V																																										
CLIBER	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
CLIBER	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CLIBER	2009	HFM (Hands Free Module)	V	V	V	V																																										
CLIBER	2009	ITM (Intrusion)	V			V																																										
CLIBER	2009	ORC (Occupant Restraint Control)	V	V		V																																										
CLIBER	2009	RADIO (Radio)	V	V		V																																										
CLIBER	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
CLIBER	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CLIBER	2009	CGW (Central Gateway)	V	V	V	V																																										
CLIBER	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
CLIBER	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CLIBER	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CLIBER	2008	AMP (Audio)	V	V		V																																										
CLIBER	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
CLIBER	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CLIBER	2008	HFM (Hands Free Module)	V	V	V	V																																										
CLIBER	2008	ITM (Intrusion)	V			V																																										
CLIBER	2008	OCM (Occupant Classification Module)	V			V																																										
CLIBER	2008	ORC (Occupant Restraint Control)	V	V		V																																										
CLIBER	2008	RADIO (Radio)	V	V		V																																										
CLIBER	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
CLIBER	2008	SDAR (Satellite Radio)	V			V																																										
CLIBER	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CLIBER	2008	CGW (Central Gateway)	V	V	V	V																																										
CLIBER	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
CLIBER	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CLIBER	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CLIBER	2007	AMP (Audio)	V	V		V																																										
CLIBER	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
CLIBER	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CLIBER	2007	HFM (Hands Free Module)	V	V	V	V																																										
CLIBER	2007	ITM (Intrusion)	V			V																																										
CLIBER	2007	OCM (Occupant Classification Module)	V			V																																										
CLIBER	2007	ORC (Occupant Restraint Control)	V	V		V																																										
CLIBER	2007	RADIO (Radio)	V	V		V																																										
CLIBER	2007	SAS (Steering Angle Sensor)	V	V	V	V																																										
CLIBER	2007	SDAR (Satellite Radio)	V			V																																										
CLIBER	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CLIBER	2007	CGW (Central Gateway)	V	V	V	V																																										
CLIBER	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
SPRINTER	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
SPRINTER	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
SPRINTER	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
SPRINTER	2009	DDM (Drivers Door Module)	V	V	V	V																																										
SPRINTER	2009	ESM (Electronic Shifter Module)	V			V																																										
SPRINTER	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
SPRINTER	2009	ORC (Occupant Restraint Control)	V	V		V																																										
SPRINTER	2009	PTS (Park Assist Module)	V			V																																										
SPRINTER	2009	RADIO (Radio)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
SPRINTER	2009	SCM (Steering Column Module)	V			V																																										
SPRINTER	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
SPRINTER	2009	TPM (Tire Pressure Monitor)	V			V																																										
SPRINTER	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
SPRINTER	2008	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
SPRINTER	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
SPRINTER	2008	DDM (Drivers Door Module)	V	V	V	V																																										
SPRINTER	2008	ESM (Electronic Shifter Module)	V			V																																										
SPRINTER	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
SPRINTER	2008	ORC (Occupant Restraint Control)	V	V		V																																										
SPRINTER	2008	PTS (Park Assist Module)	V			V																																										
SPRINTER	2008	RADIO (Radio)	V	V		V																																										
SPRINTER	2008	SCM (Steering Column Module)	V			V																																										
SPRINTER	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
SPRINTER	2008	TPM (Tire Pressure Monitor)	V			V																																										
SPRINTER	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
SPRINTER	2007	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
SPRINTER	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
SPRINTER	2007	DDM (Drivers Door Module)	V	V	V	V																																										
SPRINTER	2007	ESM (Electronic Shifter Module)	V			V																																										
SPRINTER	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
SPRINTER	2007	ORC (Occupant Restraint Control)	V	V		V																																										
SPRINTER	2007	PTS (Park Assist Module)	V			V																																										
SPRINTER	2007	RADIO (Radio)	V	V		V																																										
SPRINTER	2007	SCM (Steering Column Module)	V			V																																										
SPRINTER	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
SPRINTER	2007	TPM (Tire Pressure Monitor)	V			V																																										
CROSSFIRE	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
CROSSFIRE	2008	OCM (Occupant Classification Module)	V			V																																										
CROSSFIRE	2008	ORC (Occupant Restraint Control)	V	V		V																																										
CROSSFIRE	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
CROSSFIRE	2007	OCM (Occupant Classification Module)	V			V																																										
CROSSFIRE	2007	ORC (Occupant Restraint Control)	V	V		V																																										
JOURNEY	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
JOURNEY	2016	ABS (Anti Lock Brake System)	V			V																																										
JOURNEY	2016	AMP (Audio)	V			V																																										
JOURNEY	2016	BCM (Body Control Module)	V			V																																										
JOURNEY	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
JOURNEY	2016	CGW (Central Gateway)	V			V																																										
JOURNEY	2016	DDM (Drivers Door Module)	V			V																																										
JOURNEY	2016	DTCM (Drive Train Control Module)	V			V																																										
JOURNEY	2016	HFM (Hands Free Module)	V			V																																										
JOURNEY	2016	HSM (Heated Seat Module)	V			V																																										
JOURNEY	2016	HVAC (Heat Vent A/C)	V			V																																										
JOURNEY	2016	ICS (Integrated Center Stack)	V			V																																										
JOURNEY	2016	IPC (Instrument Panel Cluster)	V			V																																										
JOURNEY	2016	ITM (Intrusion)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
JOURNEY	2016	ORC (Occupant Restraint Control)	V			V																																										
JOURNEY	2016	PDM (Passenger Door Module)	V			V																																										
JOURNEY	2016	PTS (Park Assist Module)	V			V																																										
JOURNEY	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
JOURNEY	2016	RFH (Radio Frequency Hub)	V			V																																										
JOURNEY	2016	SCM (Steering Column Module)	V			V																																										
JOURNEY	2016	TCM (Transmission Control Module)	V			V																																										
JOURNEY	2016	TGW (Telematics Gateway)	V			V																																										
JOURNEY	2016	TPM (Tire Pressure Monitor)	V			V																																										
JOURNEY	2016	VES3 (Vidio Entertainment System 3)	V			V																																										
JOURNEY	2016	WCM(Wireless Control Modules)	V			V																																										
JOURNEY	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
JOURNEY	2015	ABS (Anti Lock Brake System)	V			V																																										
JOURNEY	2015	AMP (Audio)	V			V																																										
JOURNEY	2015	BCM (Body Control Module)	V			V																																										
JOURNEY	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
JOURNEY	2015	CGW (Central Gateway)	V			V																																										
JOURNEY	2015	DDM (Drivers Door Module)	V			V																																										
JOURNEY	2015	DTCM (Drive Train Control Module)	V			V																																										
JOURNEY	2015	HFM (Hands Free Module)	V			V																																										
JOURNEY	2015	HSM (Heated Seat Module)	V			V																																										
JOURNEY	2015	HVAC (Heat Vent A/C)	V			V																																										
JOURNEY	2015	ICS (Integrated Center Stack)	V			V																																										
JOURNEY	2015	IPC (Instrument Panel Cluster)	V			V																																										
JOURNEY	2015	ITM (Intrusion)	V			V																																										
JOURNEY	2015	ORC (Occupant Restraint Control)	V			V																																										
JOURNEY	2015	PDM (Passenger Door Module)	V			V																																										
JOURNEY	2015	PTS (Park Assist Module)	V			V																																										
JOURNEY	2015	RBSS (Right Blind Spot Sensor)	V			V																																										
JOURNEY	2015	RFH (Radio Frequency Hub)	V			V																																										
JOURNEY	2015	SCM (Steering Column Module)	V			V																																										
JOURNEY	2015	TCM (Transmission Control Module)	V			V																																										
JOURNEY	2015	TGW (Telematics Gateway)	V			V																																										
JOURNEY	2015	TPM (Tire Pressure Monitor)	V			V																																										
JOURNEY	2015	VES3 (Vidio Entertainment System 3)	V			V																																										
JOURNEY	2015	WCM(Wireless Control Modules)	V			V																																										
JOURNEY	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
JOURNEY	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
JOURNEY	2014	AMP (Audio)	V	V		V																																										
JOURNEY	2014	DDM (Drivers Door Module)	V	V	V	V																																										
JOURNEY	2014	DTCM (Drive Train Control Module)	V			V																																										
JOURNEY	2014	HFM (Hands Free Module)	V	V	V	V																																										
JOURNEY	2014	HSM (Heated Seat Module)	V			V																																										
JOURNEY	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
JOURNEY	2014	ITM (Intrusion)	V			V																																										
JOURNEY	2014	ORC (Occupant Restraint Control)	V	V		V																																										
JOURNEY	2014	PDM (Passenger Door Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
JOURNEY	2014	PTS (Park Assist Module)	V			V																																										
JOURNEY	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
JOURNEY	2014	TPM (Tire Pressure Monitor)	V			V																																										
JOURNEY	2014	VES3 (Vidio Entertainment System 3)	V			V																																										
JOURNEY	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
JOURNEY	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
JOURNEY	2013	AMP (Audio)	V	V		V																																										
JOURNEY	2013	DDM (Drivers Door Module)	V	V	V	V																																										
JOURNEY	2013	DTCM (Drive Train Control Module)	V			V																																										
JOURNEY	2013	HFM (Hands Free Module)	V	V	V	V																																										
JOURNEY	2013	HSM (Heated Seat Module)	V			V																																										
JOURNEY	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
JOURNEY	2013	ITM (Intrusion)	V			V																																										
JOURNEY	2013	ORC (Occupant Restraint Control)	V	V		V																																										
JOURNEY	2013	PDM (Passenger Door Module)	V	V	V	V																																										
JOURNEY	2013	PTS (Park Assist Module)	V			V																																										
JOURNEY	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
JOURNEY	2013	TPM (Tire Pressure Monitor)	V			V																																										
JOURNEY	2013	VES3 (Vidio Entertainment System 3)	V			V																																										
JOURNEY	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
JOURNEY	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
JOURNEY	2012	AMP (Audio)	V	V		V																																										
JOURNEY	2012	DDM (Drivers Door Module)	V	V	V	V																																										
JOURNEY	2012	DTCM (Drive Train Control Module)	V			V																																										
JOURNEY	2012	HFM (Hands Free Module)	V	V	V	V																																										
JOURNEY	2012	HSM (Heated Seat Module)	V			V																																										
JOURNEY	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
JOURNEY	2012	ITM (Intrusion)	V			V																																										
JOURNEY	2012	ORC (Occupant Restraint Control)	V	V		V																																										
JOURNEY	2012	PDM (Passenger Door Module)	V	V	V	V																																										
JOURNEY	2012	PTS (Park Assist Module)	V			V																																										
JOURNEY	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
JOURNEY	2012	TPM (Tire Pressure Monitor)	V			V																																										
JOURNEY	2012	VES3 (Vidio Entertainment System 3)	V			V																																										
JOURNEY	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
JOURNEY	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
JOURNEY	2011	AMP (Audio)	V	V		V																																										
JOURNEY	2011	DDM (Drivers Door Module)	V	V	V	V																																										
JOURNEY	2011	DTCM (Drive Train Control Module)	V			V																																										
JOURNEY	2011	HFM (Hands Free Module)	V	V	V	V																																										
JOURNEY	2011	HSM (Heated Seat Module)	V			V																																										
JOURNEY	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
JOURNEY	2011	ITM (Intrusion)	V			V																																										
JOURNEY	2011	ORC (Occupant Restraint Control)	V	V		V																																										
JOURNEY	2011	PDM (Passenger Door Module)	V	V	V	V																																										
JOURNEY	2011	PTS (Park Assist Module)	V			V																																										
JOURNEY	2011	TPM (Tire Pressure Monitor)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
JOURNEY	2011	VES3 (Vidio Entertainment System 3)	V			V																																										
JOURNEY	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
JOURNEY	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
JOURNEY	2010	AMP (Audio)	V	V		V																																										
JOURNEY	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
JOURNEY	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
JOURNEY	2010	HFM (Hands Free Module)	V	V	V	V																																										
JOURNEY	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
JOURNEY	2010	ITM (Intrusion)	V			V																																										
JOURNEY	2010	ORC (Occupant Restraint Control)	V	V		V																																										
JOURNEY	2010	RADIO (Radio)	V	V		V																																										
JOURNEY	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
JOURNEY	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
JOURNEY	2010	CGW (Central Gateway)	V	V	V	V																																										
JOURNEY	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
JOURNEY	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
JOURNEY	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
JOURNEY	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
JOURNEY	2009	AMP (Audio)	V	V		V																																										
JOURNEY	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
JOURNEY	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
JOURNEY	2009	HFM (Hands Free Module)	V	V	V	V																																										
JOURNEY	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
JOURNEY	2009	ITM (Intrusion)	V			V																																										
JOURNEY	2009	ORC (Occupant Restraint Control)	V	V		V																																										
JOURNEY	2009	RADIO (Radio)	V	V		V																																										
JOURNEY	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
JOURNEY	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
JOURNEY	2009	CGW (Central Gateway)	V	V	V	V																																										
JOURNEY	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
JOURNEY	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
JOURNEY	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
JOURNEY	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
JOURNEY	2008	AMP (Audio)	V	V		V																																										
JOURNEY	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
JOURNEY	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
JOURNEY	2008	HFM (Hands Free Module)	V	V	V	V																																										
JOURNEY	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
JOURNEY	2008	ITM (Intrusion)	V			V																																										
JOURNEY	2008	ORC (Occupant Restraint Control)	V	V		V																																										
JOURNEY	2008	RADIO (Radio)	V	V		V																																										
JOURNEY	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
JOURNEY	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
JOURNEY	2008	CGW (Central Gateway)	V	V	V	V																																										
JOURNEY	2008	VES3 (Vidio Entertainment System 3)	V			V																																										
JOURNEY	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
CHALLENGER	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CHALLENGER	2016	ABS (Anti Lock Brake System)	V			V																																										
CHALLENGER	2016	ACC (Adaptive Cruise Control)	V			V																																										
CHALLENGER	2016	ADCM (Adaptive Damper Control Module)	V			V																																										
CHALLENGER	2016	AMP (Audio)	V			V																																										
CHALLENGER	2016	BCM (Body Control Module)	V			V																																										
CHALLENGER	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
CHALLENGER	2016	CGW (Central Gateway)	V			V																																										
CHALLENGER	2016	DDM (Drivers Door Module)	V			V																																										
CHALLENGER	2016	EPS (Electric Power Steering)	V			V																																										
CHALLENGER	2016	ESM (Electronic Shifter Module)	V			V																																										
CHALLENGER	2016	HSM (Heated Seat Module)	V			V																																										
CHALLENGER	2016	HVAC (Heat Vent A/C)	V			V																																										
CHALLENGER	2016	ICS (Integrated Center Stack)	V			V																																										
CHALLENGER	2016	IPC (Instrument Panel Cluster)	V			V																																										
CHALLENGER	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
CHALLENGER	2016	MSMD (Memory Seet Module)	V			V																																										
CHALLENGER	2016	ORC (Occupant Restraint Control)	V			V																																										
CHALLENGER	2016	PDM (Passenger Door Module)	V			V																																										
CHALLENGER	2016	PTS (Park Assist Module)	V			V																																										
CHALLENGER	2016	RADIO (Radio)	V			V																																										
CHALLENGER	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
CHALLENGER	2016	RFH (Radio Frequency Hub)	V			V																																										
CHALLENGER	2016	SCM (Steering Column Module)	V			V																																										
CHALLENGER	2016	TCM (Transmission Control Module)	V			V																																										
CHALLENGER	2016	TPM (Tire Pressure Monitor)	V			V																																										
CHALLENGER	2016	WCM(Wireless Control Modules)	V			V																																										
CHALLENGER	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V											
CHALLENGER	2015	ABS (Anti Lock Brake System)	V			V																																										
CHALLENGER	2015	ACC (Adaptive Cruise Control)	V			V																																										
CHALLENGER	2015	ADCM (Adaptive Damper Control Module)	V			V																																										
CHALLENGER	2015	AMP (Audio)	V			V																																										
CHALLENGER	2015	BCM (Body Control Module)	V			V																																										
CHALLENGER	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
CHALLENGER	2015	CGW (Central Gateway)	V			V																																										
CHALLENGER	2015	DDM (Drivers Door Module)	V			V																																										
CHALLENGER	2015	EPS (Electric Power Steering)	V			V																																										
CHALLENGER	2015	ESM (Electronic Shifter Module)	V			V																																										
CHALLENGER	2015	HSM (Heated Seat Module)	V			V																																										
CHALLENGER	2015	HVAC (Heat Vent A/C)	V			V																																										
CHALLENGER	2015	ICS (Integrated Center Stack)	V			V																																										
CHALLENGER	2015	IPC (Instrument Panel Cluster)	V			V																																										
CHALLENGER	2015	LBSS (Left Blind Spot Sensor)	V			V																																										
CHALLENGER	2015	MSMD (Memory Seet Module)	V			V																																										
CHALLENGER	2015	ORC (Occupant Restraint Control)	V			V																																										
CHALLENGER	2015	PDM (Passenger Door Module)	V			V																																										
CHALLENGER	2015	PTS (Park Assist Module)	V			V																																										
CHALLENGER	2015	RADIO (Radio)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CHALLENGER	2015	RBSS (Right Blind Spot Sensor)	V			V																																										
CHALLENGER	2015	RFH (Radio Frequency Hub)	V			V																																										
CHALLENGER	2015	SCM (Steering Column Module)	V			V																																										
CHALLENGER	2015	TCM (Transmission Control Module)	V			V																																										
CHALLENGER	2015	TPM (Tire Pressure Monitor)	V			V																																										
CHALLENGER	2015	WCM(Wireless Control Modules)	V			V																																										
CHALLENGER	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHALLENGER	2014	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CHALLENGER	2014	AMP (Audio)	V	V		V																																										
CHALLENGER	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHALLENGER	2014	DDM (Drivers Door Module)	V	V	V	V																																										
CHALLENGER	2014	EOM (Electric Overhead Module)	V	V	V	V																																										
CHALLENGER	2014	ESM (Electronic Shifter Module)	V			V																																										
CHALLENGER	2014	HFM (Hands Free Module)	V	V	V	V																																										
CHALLENGER	2014	HSM (Heated Seat Module)	V			V																																										
CHALLENGER	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHALLENGER	2014	ORC (Occupant Restraint Control)	V	V		V																																										
CHALLENGER	2014	PDM (Passenger Door Module)	V	V	V	V																																										
CHALLENGER	2014	PTS (Park Assist Module)	V			V																																										
CHALLENGER	2014	RADIO (Radio)	V	V		V																																										
CHALLENGER	2014	SAS (Steering Angle Sensor)	V	V	V	V																																										
CHALLENGER	2014	SUNR (Sunroof Module)	V			V																																										
CHALLENGER	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHALLENGER	2014	CGW (Central Gateway)	V	V	V	V																																										
CHALLENGER	2014	TPM (Tire Pressure Monitor)	V			V																																										
CHALLENGER	2014	WCM(Wireless Control Modules)	V	V	V	V																																										
CHALLENGER	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHALLENGER	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CHALLENGER	2013	AMP (Audio)	V	V		V																																										
CHALLENGER	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHALLENGER	2013	DDM (Drivers Door Module)	V	V	V	V																																										
CHALLENGER	2013	EOM (Electric Overhead Module)	V	V	V	V																																										
CHALLENGER	2013	ESM (Electronic Shifter Module)	V			V																																										
CHALLENGER	2013	HFM (Hands Free Module)	V	V	V	V																																										
CHALLENGER	2013	HSM (Heated Seat Module)	V			V																																										
CHALLENGER	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHALLENGER	2013	ORC (Occupant Restraint Control)	V	V		V																																										
CHALLENGER	2013	PDM (Passenger Door Module)	V	V	V	V																																										
CHALLENGER	2013	PTS (Park Assist Module)	V			V																																										
CHALLENGER	2013	RADIO (Radio)	V	V		V																																										
CHALLENGER	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
CHALLENGER	2013	SUNR (Sunroof Module)	V			V																																										
CHALLENGER	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHALLENGER	2013	CGW (Central Gateway)	V	V	V	V																																										
CHALLENGER	2013	TPM (Tire Pressure Monitor)	V			V																																										
CHALLENGER	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
CHALLENGER	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CHALLENGER	2012	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
CHALLENGER	2012	AMP (Audio)	V	V		V																																										
CHALLENGER	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHALLENGER	2012	DDM (Drivers Door Module)	V	V	V	V																																										
CHALLENGER	2012	EOM (Electric Overhead Module)	V	V	V	V																																										
CHALLENGER	2012	ESM (Electronic Shifter Module)	V			V																																										
CHALLENGER	2012	HFM (Hands Free Module)	V	V	V	V																																										
CHALLENGER	2012	HSM (Heated Seat Module)	V			V																																										
CHALLENGER	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHALLENGER	2012	ORC (Occupant Restraint Control)	V	V		V																																										
CHALLENGER	2012	PDM (Passenger Door Module)	V	V	V	V																																										
CHALLENGER	2012	RADIO (Radio)	V	V		V																																										
CHALLENGER	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
CHALLENGER	2012	SUNR (Sunroof Module)	V			V																																										
CHALLENGER	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHALLENGER	2012	CGW (Central Gateway)	V	V	V	V																																										
CHALLENGER	2012	TPM (Tire Pressure Monitor)	V			V																																										
CHALLENGER	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
CHALLENGER	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
CHALLENGER	2011	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
CHALLENGER	2011	AMP (Audio)	V	V		V																																										
CHALLENGER	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHALLENGER	2011	DDM (Drivers Door Module)	V	V	V	V																																										
CHALLENGER	2011	EOM (Electric Overhead Module)	V	V	V	V																																										
CHALLENGER	2011	ESM (Electronic Shifter Module)	V			V																																										
CHALLENGER	2011	HFM (Hands Free Module)	V	V	V	V																																										
CHALLENGER	2011	HSM (Heated Seat Module)	V			V																																										
CHALLENGER	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHALLENGER	2011	ORC (Occupant Restraint Control)	V	V		V																																										
CHALLENGER	2011	PDM (Passenger Door Module)	V	V	V	V																																										
CHALLENGER	2011	RADIO (Radio)	V	V		V																																										
CHALLENGER	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
CHALLENGER	2011	SUNR (Sunroof Module)	V			V																																										
CHALLENGER	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHALLENGER	2011	CGW (Central Gateway)	V	V	V	V																																										
CHALLENGER	2011	TPM (Tire Pressure Monitor)	V			V																																										
CHALLENGER	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
CHALLENGER	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
CHALLENGER	2010	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
CHALLENGER	2010	AMP (Audio)	V	V		V																																										
CHALLENGER	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHALLENGER	2010	DDM (Drivers Door Module)	V	V	V	V																																										
CHALLENGER	2010	EOM (Electric Overhead Module)	V	V	V	V																																										
CHALLENGER	2010	ESM (Electronic Shifter Module)	V			V																																										
CHALLENGER	2010	HFM (Hands Free Module)	V	V	V	V																																										
CHALLENGER	2010	HSM (Heated Seat Module)	V			V																																										
CHALLENGER	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CHALLENGER	2010	ORC (Occupant Restraint Control)	V	V		V																																										
CHALLENGER	2010	PDM (Passenger Door Module)	V	V	V	V																																										
CHALLENGER	2010	RADIO (Radio)	V	V		V																																										
CHALLENGER	2010	SCM (Steering Column Module)	V			V																																										
CHALLENGER	2010	SUNR (Sunroof Module)	V			V																																										
CHALLENGER	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHALLENGER	2010	CGW (Central Gateway)	V	V	V	V																																										
CHALLENGER	2010	TPM (Tire Pressure Monitor)	V			V																																										
CHALLENGER	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
CHALLENGER	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHALLENGER	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CHALLENGER	2009	AMP (Audio)	V	V		V																																										
CHALLENGER	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHALLENGER	2009	DDM (Drivers Door Module)	V	V	V	V																																										
CHALLENGER	2009	EOM (Electric Overhead Module)	V	V	V	V																																										
CHALLENGER	2009	ESM (Electronic Shifter Module)	V			V																																										
CHALLENGER	2009	HFM (Hands Free Module)	V	V	V	V																																										
CHALLENGER	2009	HSM (Heated Seat Module)	V			V																																										
CHALLENGER	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHALLENGER	2009	ORC (Occupant Restraint Control)	V	V		V																																										
CHALLENGER	2009	PDM (Passenger Door Module)	V	V	V	V																																										
CHALLENGER	2009	RADIO (Radio)	V	V		V																																										
CHALLENGER	2009	SCM (Steering Column Module)	V			V																																										
CHALLENGER	2009	SUNR (Sunroof Module)	V			V																																										
CHALLENGER	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHALLENGER	2009	CGW (Central Gateway)	V	V	V	V																																										
CHALLENGER	2009	TPM (Tire Pressure Monitor)	V			V																																										
CHALLENGER	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
CHALLENGER	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHALLENGER	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
CHALLENGER	2008	AMP (Audio)	V	V		V																																										
CHALLENGER	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
CHALLENGER	2008	DDM (Drivers Door Module)	V	V	V	V																																										
CHALLENGER	2008	EOM (Electric Overhead Module)	V	V	V	V																																										
CHALLENGER	2008	ESM (Electronic Shifter Module)	V			V																																										
CHALLENGER	2008	HFM (Hands Free Module)	V	V	V	V																																										
CHALLENGER	2008	HSM (Heated Seat Module)	V			V																																										
CHALLENGER	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
CHALLENGER	2008	ORC (Occupant Restraint Control)	V	V		V																																										
CHALLENGER	2008	PDM (Passenger Door Module)	V	V	V	V																																										
CHALLENGER	2008	RADIO (Radio)	V	V		V																																										
CHALLENGER	2008	SCM (Steering Column Module)	V			V																																										
CHALLENGER	2008	SUNR (Sunroof Module)	V			V																																										
CHALLENGER	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
CHALLENGER	2008	CGW (Central Gateway)	V	V	V	V																																										
CHALLENGER	2008	TPM (Tire Pressure Monitor)	V			V																																										
CHALLENGER	2008	WCM(Wireless Control Modules)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND CARAVAN	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CARAVAN	2016	ABS (Anti Lock Brake System)	V			V																																										
GRAND CARAVAN	2016	AHBM (Automatic High Beam)	V			V																																										
GRAND CARAVAN	2016	AMP (Audio)	V			V																																										
GRAND CARAVAN	2016	BCM (Body Control Module)	V			V																																										
GRAND CARAVAN	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
GRAND CARAVAN	2016	CGW (Central Gateway)	V			V																																										
GRAND CARAVAN	2016	HFM (Hands Free Module)	V			V																																										
GRAND CARAVAN	2016	HVAC (Heat Vent A/C)	V			V																																										
GRAND CARAVAN	2016	IPC (Instrument Panel Cluster)	V			V																																										
GRAND CARAVAN	2016	ITM (Intrusion)	V			V																																										
GRAND CARAVAN	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
GRAND CARAVAN	2016	MSMD (Memory Seet Module)	V			V																																										
GRAND CARAVAN	2016	ORC (Occupant Restraint Control)	V			V																																										
GRAND CARAVAN	2016	PTS (Park Assist Module)	V			V																																										
GRAND CARAVAN	2016	RADIO (Radio)	V			V																																										
GRAND CARAVAN	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
GRAND CARAVAN	2016	RFH (Radio Frequency Hub)	V			V																																										
GRAND CARAVAN	2016	SAS (Steering Angle Sensor)	V			V																																										
GRAND CARAVAN	2016	SUNR (Sunroof Module)	V			V																																										
GRAND CARAVAN	2016	TCM (Transmission Control Module)	V			V																																										
GRAND CARAVAN	2016	TPM (Tire Pressure Monitor)	V			V																																										
GRAND CARAVAN	2016	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CARAVAN	2016	WCM(Wireless Control Modules)	V			V																																										
GRAND CARAVAN	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CARAVAN	2015	ABS (Anti Lock Brake System)	V			V																																										
GRAND CARAVAN	2015	AHBM (Automatic High Beam)	V			V																																										
GRAND CARAVAN	2015	AMP (Audio)	V			V																																										
GRAND CARAVAN	2015	BCM (Body Control Module)	V			V																																										
GRAND CARAVAN	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
GRAND CARAVAN	2015	CGW (Central Gateway)	V			V																																										
GRAND CARAVAN	2015	HFM (Hands Free Module)	V			V																																										
GRAND CARAVAN	2015	HVAC (Heat Vent A/C)	V			V																																										
GRAND CARAVAN	2015	IPC (Instrument Panel Cluster)	V			V																																										
GRAND CARAVAN	2015	ITM (Intrusion)	V			V																																										
GRAND CARAVAN	2015	LBSS (Left Blind Spot Sensor)	V			V																																										
GRAND CARAVAN	2015	MSMD (Memory Seet Module)	V			V																																										
GRAND CARAVAN	2015	ORC (Occupant Restraint Control)	V			V																																										
GRAND CARAVAN	2015	PTS (Park Assist Module)	V			V																																										
GRAND CARAVAN	2015	RADIO (Radio)	V			V																																										
GRAND CARAVAN	2015	RBSS (Right Blind Spot Sensor)	V			V																																										
GRAND CARAVAN	2015	RFH (Radio Frequency Hub)	V			V																																										
GRAND CARAVAN	2015	SAS (Steering Angle Sensor)	V			V																																										
GRAND CARAVAN	2015	SUNR (Sunroof Module)	V			V																																										
GRAND CARAVAN	2015	TCM (Transmission Control Module)	V			V																																										
GRAND CARAVAN	2015	TPM (Tire Pressure Monitor)	V			V																																										
GRAND CARAVAN	2015	VES3 (Vidio Entertainment System 3)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND CARAVAN	2015	WCM(Wireless Control Modules)	V			V																																										
GRAND CARAVAN	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CARAVAN	2014	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CARAVAN	2014	AHBM (Automatic High Beam)	V			V																																										
GRAND CARAVAN	2014	AMP (Audio)	V	V		V																																										
GRAND CARAVAN	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CARAVAN	2014	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CARAVAN	2014	HSM (Heated Seat Module)	V			V																																										
GRAND CARAVAN	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CARAVAN	2014	ITM (Intrusion)	V			V																																										
GRAND CARAVAN	2014	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CARAVAN	2014	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CARAVAN	2014	PLM (Power Liftgate Module)	V			V																																										
GRAND CARAVAN	2014	PTS (Park Assist Module)	V			V																																										
GRAND CARAVAN	2014	RADIO (Radio)	V	V		V																																										
GRAND CARAVAN	2014	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CARAVAN	2014	SUNR (Sunroof Module)	V			V																																										
GRAND CARAVAN	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CARAVAN	2014	CGW (Central Gateway)	V	V	V	V																																										
GRAND CARAVAN	2014	TPM (Tire Pressure Monitor)	V			V																																										
GRAND CARAVAN	2014	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CARAVAN	2014	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CARAVAN	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CARAVAN	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CARAVAN	2013	AHBM (Automatic High Beam)	V			V																																										
GRAND CARAVAN	2013	AMP (Audio)	V	V		V																																										
GRAND CARAVAN	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CARAVAN	2013	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CARAVAN	2013	HSM (Heated Seat Module)	V			V																																										
GRAND CARAVAN	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CARAVAN	2013	ITM (Intrusion)	V			V																																										
GRAND CARAVAN	2013	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CARAVAN	2013	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CARAVAN	2013	PLM (Power Liftgate Module)	V			V																																										
GRAND CARAVAN	2013	PTS (Park Assist Module)	V			V																																										
GRAND CARAVAN	2013	RADIO (Radio)	V	V		V																																										
GRAND CARAVAN	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CARAVAN	2013	SUNR (Sunroof Module)	V			V																																										
GRAND CARAVAN	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CARAVAN	2013	CGW (Central Gateway)	V	V	V	V																																										
GRAND CARAVAN	2013	TPM (Tire Pressure Monitor)	V			V																																										
GRAND CARAVAN	2013	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CARAVAN	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CARAVAN	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CARAVAN	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CARAVAN	2012	AHBM (Automatic High Beam)	V			V																																										
GRAND CARAVAN	2012	AMP (Audio)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND CARAVAN	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CARAVAN	2012	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CARAVAN	2012	HSM (Heated Seat Module)	V			V																																										
GRAND CARAVAN	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CARAVAN	2012	ITM (Intrusion)	V			V																																										
GRAND CARAVAN	2012	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CARAVAN	2012	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CARAVAN	2012	PLM (Power Liftgate Module)	V			V																																										
GRAND CARAVAN	2012	PTS (Park Assist Module)	V			V																																										
GRAND CARAVAN	2012	RADIO (Radio)	V	V		V																																										
GRAND CARAVAN	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CARAVAN	2012	SUNR (Sunroof Module)	V			V																																										
GRAND CARAVAN	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V					
GRAND CARAVAN	2012	CGW (Central Gateway)	V	V	V	V																																										
GRAND CARAVAN	2012	TPM (Tire Pressure Monitor)	V			V																																										
GRAND CARAVAN	2012	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CARAVAN	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CARAVAN	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CARAVAN	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CARAVAN	2011	AHBM (Automatic High Beam)	V			V																																										
GRAND CARAVAN	2011	AMP (Audio)	V	V		V																																										
GRAND CARAVAN	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CARAVAN	2011	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CARAVAN	2011	HSM (Heated Seat Module)	V			V																																										
GRAND CARAVAN	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CARAVAN	2011	ITM (Intrusion)	V			V																																										
GRAND CARAVAN	2011	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CARAVAN	2011	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CARAVAN	2011	PLM (Power Liftgate Module)	V			V																																										
GRAND CARAVAN	2011	PTS (Park Assist Module)	V			V																																										
GRAND CARAVAN	2011	RADIO (Radio)	V	V		V																																										
GRAND CARAVAN	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CARAVAN	2011	SUNR (Sunroof Module)	V			V																																										
GRAND CARAVAN	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V					
GRAND CARAVAN	2011	CGW (Central Gateway)	V	V	V	V																																										
GRAND CARAVAN	2011	TPM (Tire Pressure Monitor)	V			V																																										
GRAND CARAVAN	2011	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CARAVAN	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CARAVAN	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CARAVAN	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CARAVAN	2010	AHBM (Automatic High Beam)	V			V																																										
GRAND CARAVAN	2010	AMP (Audio)	V	V		V																																										
GRAND CARAVAN	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CARAVAN	2010	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CARAVAN	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CARAVAN	2010	ITM (Intrusion)	V			V																																										
GRAND CARAVAN	2010	MSMD (Memory Seet Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND CARAVAN	2010	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CARAVAN	2010	PLM (Power Liftgate Module)	V			V																																										
GRAND CARAVAN	2010	PTS (Park Assist Module)	V			V																																										
GRAND CARAVAN	2010	RADIO (Radio)	V	V		V																																										
GRAND CARAVAN	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CARAVAN	2010	SUNR (Sunroof Module)	V			V																																										
GRAND CARAVAN	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CARAVAN	2010	CGW (Central Gateway)	V	V	V	V																																										
GRAND CARAVAN	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CARAVAN	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CARAVAN	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CARAVAN	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CARAVAN	2009	AHBM (Automatic High Beam)	V			V																																										
GRAND CARAVAN	2009	AMP (Audio)	V	V		V																																										
GRAND CARAVAN	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CARAVAN	2009	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CARAVAN	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CARAVAN	2009	ITM (Intrusion)	V			V																																										
GRAND CARAVAN	2009	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CARAVAN	2009	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CARAVAN	2009	PLM (Power Liftgate Module)	V			V																																										
GRAND CARAVAN	2009	PTS (Park Assist Module)	V			V																																										
GRAND CARAVAN	2009	RADIO (Radio)	V	V		V																																										
GRAND CARAVAN	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CARAVAN	2009	SUNR (Sunroof Module)	V			V																																										
GRAND CARAVAN	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CARAVAN	2009	CGW (Central Gateway)	V	V	V	V																																										
GRAND CARAVAN	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CARAVAN	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CARAVAN	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CARAVAN	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CARAVAN	2008	AHBM (Automatic High Beam)	V			V																																										
GRAND CARAVAN	2008	AMP (Audio)	V	V		V																																										
GRAND CARAVAN	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CARAVAN	2008	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CARAVAN	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CARAVAN	2008	ITM (Intrusion)	V			V																																										
GRAND CARAVAN	2008	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CARAVAN	2008	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CARAVAN	2008	PLM (Power Liftgate Module)	V			V																																										
GRAND CARAVAN	2008	PTS (Park Assist Module)	V			V																																										
GRAND CARAVAN	2008	RADIO (Radio)	V	V		V																																										
GRAND CARAVAN	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CARAVAN	2008	SUNR (Sunroof Module)	V			V																																										
GRAND CARAVAN	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CARAVAN	2008	CGW (Central Gateway)	V	V	V	V																																										
GRAND CARAVAN	2008	VES3 (Vidio Entertainment System 3)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND CARAVAN	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
DODGE RAM	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DODGE RAM	2010	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
DODGE RAM	2010	AMP (Audio)	V	V		V																																										
DODGE RAM	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DODGE RAM	2010	EOM (Electric Overhead Module)	V	V	V	V																																										
DODGE RAM	2010	HFM (Hands Free Module)	V	V	V	V																																										
DODGE RAM	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
DODGE RAM	2010	ORC (Occupant Restraint Control)	V	V		V																																										
DODGE RAM	2010	RADIO (Radio)	V	V		V																																										
DODGE RAM	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
DODGE RAM	2010	SDAR (Satellite Radio)	V			V																																										
DODGE RAM	2010	SUNR (Sunroof Module)	V			V																																										
DODGE RAM	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DODGE RAM	2010	CGW (Central Gateway)	V	V	V	V																																										
DODGE RAM	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
DODGE RAM	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DODGE RAM	2009	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
DODGE RAM	2009	AMP (Audio)	V	V		V																																										
DODGE RAM	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DODGE RAM	2009	EOM (Electric Overhead Module)	V	V	V	V																																										
DODGE RAM	2009	HFM (Hands Free Module)	V	V	V	V																																										
DODGE RAM	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
DODGE RAM	2009	ORC (Occupant Restraint Control)	V	V		V																																										
DODGE RAM	2009	RADIO (Radio)	V	V		V																																										
DODGE RAM	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
DODGE RAM	2009	SDAR (Satellite Radio)	V			V																																										
DODGE RAM	2009	SUNR (Sunroof Module)	V			V																																										
DODGE RAM	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DODGE RAM	2009	CGW (Central Gateway)	V	V	V	V																																										
DODGE RAM	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
DODGE RAM	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DODGE RAM	2008	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
DODGE RAM	2008	AMP (Audio)	V	V		V																																										
DODGE RAM	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DODGE RAM	2008	EOM (Electric Overhead Module)	V	V	V	V																																										
DODGE RAM	2008	HFM (Hands Free Module)	V	V	V	V																																										
DODGE RAM	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
DODGE RAM	2008	ORC (Occupant Restraint Control)	V	V		V																																										
DODGE RAM	2008	RADIO (Radio)	V	V		V																																										
DODGE RAM	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
DODGE RAM	2008	SDAR (Satellite Radio)	V			V																																										
DODGE RAM	2008	SUNR (Sunroof Module)	V			V																																										
DODGE RAM	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DODGE RAM	2008	CGW (Central Gateway)	V	V	V	V																																										
DODGE RAM	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
DODGE RAM	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
DODGE RAM	2007	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
DODGE RAM	2007	AMP (Audio)	V	V		V																																										
DODGE RAM	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DODGE RAM	2007	EOM (Electric Overhead Module)	V	V	V	V																																										
DODGE RAM	2007	HFM (Hands Free Module)	V	V	V	V																																										
DODGE RAM	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
DODGE RAM	2007	ORC (Occupant Restraint Control)	V	V		V																																										
DODGE RAM	2007	RADIO (Radio)	V	V		V																																										
DODGE RAM	2007	SAS (Steering Angle Sensor)	V	V	V	V																																										
DODGE RAM	2007	SDAR (Satellite Radio)	V			V																																										
DODGE RAM	2007	SUNR (Sunroof Module)	V			V																																										
DODGE RAM	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DODGE RAM	2007	CGW (Central Gateway)	V	V	V	V																																										
DODGE RAM	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
DODGE RAM	2006	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DODGE RAM	2006	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
DODGE RAM	2006	AMP (Audio)	V	V		V																																										
DODGE RAM	2006	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
DODGE RAM	2006	EOM (Electric Overhead Module)	V	V	V	V																																										
DODGE RAM	2006	HFM (Hands Free Module)	V	V	V	V																																										
DODGE RAM	2006	HVAC (Heat Vent A/C)	V	V	V	V																																										
DODGE RAM	2006	OCM (Occupant Classification Module)	V			V																																										
DODGE RAM	2006	ORC (Occupant Restraint Control)	V	V		V																																										
DODGE RAM	2006	RADIO (Radio)	V	V		V																																										
DODGE RAM	2006	SDAR (Satellite Radio)	V			V																																										
DODGE RAM	2006	SUNR (Sunroof Module)	V			V																																										
DODGE RAM	2006	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
DODGE RAM	2006	CGW (Central Gateway)	V	V	V	V																																										
DODGE RAM	2006	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 1500	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 1500	2016	ABS (Anti Lock Brake System)	V			V																																										
RAM 1500	2016	AMP (Audio)	V			V																																										
RAM 1500	2016	BCM (Body Control Module)	V			V																																										
RAM 1500	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM 1500	2016	CGW (Central Gateway)	V			V																																										
RAM 1500	2016	DDM (Drivers Door Module)	V			V																																										
RAM 1500	2016	DTCM (Drive Train Control Module)	V			V																																										
RAM 1500	2016	EDM (Electronic Damper Module)	V			V																																										
RAM 1500	2016	EPS (Electric Power Steering)	V			V																																										
RAM 1500	2016	ESM (Electronic Shifter Module)	V			V																																										
RAM 1500	2016	HSM (Heated Seat Module)	V			V																																										
RAM 1500	2016	HVAC (Heat Vent A/C)	V			V																																										
RAM 1500	2016	ICS (Integrated Center Stack)	V			V																																										
RAM 1500	2016	IPC (Instrument Panel Cluster)	V			V																																										
RAM 1500	2016	MSMD (Memory Seet Module)	V			V																																										
RAM 1500	2016	ORC (Occupant Restraint Control)	V			V																																										
RAM 1500	2016	PDM (Passenger Door Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 1500	2016	PTS (Park Assist Module)	V			V																																										
RAM 1500	2016	RADIO (Radio)	V			V																																										
RAM 1500	2016	RFH (Radio Frequency Hub)	V			V																																										
RAM 1500	2016	SCM (Steering Column Module)	V			V																																										
RAM 1500	2016	TCM (Transmission Control Module)	V			V																																										
RAM 1500	2016	WCM(Wireless Control Modules)	V			V																																										
RAM 1500	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 1500	2015	ABS (Anti Lock Brake System)	V			V																																										
RAM 1500	2015	AMP (Audio)	V			V																																										
RAM 1500	2015	BCM (Body Control Module)	V			V																																										
RAM 1500	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM 1500	2015	CGW (Central Gateway)	V			V																																										
RAM 1500	2015	DDM (Drivers Door Module)	V			V																																										
RAM 1500	2015	DTCM (Drive Train Control Module)	V			V																																										
RAM 1500	2015	EDM (Electronic Damper Module)	V			V																																										
RAM 1500	2015	EPS (Electric Power Steering)	V			V																																										
RAM 1500	2015	ESM (Electronic Shifter Module)	V			V																																										
RAM 1500	2015	HSM (Heated Seat Module)	V			V																																										
RAM 1500	2015	HVAC (Heat Vent A/C)	V			V																																										
RAM 1500	2015	ICS (Integrated Center Stack)	V			V																																										
RAM 1500	2015	IPC (Instrument Panel Cluster)	V			V																																										
RAM 1500	2015	MSMD (Memory Seet Module)	V			V																																										
RAM 1500	2015	ORC (Occupant Restraint Control)	V			V																																										
RAM 1500	2015	PDM (Passenger Door Module)	V			V																																										
RAM 1500	2015	PTS (Park Assist Module)	V			V																																										
RAM 1500	2015	RADIO (Radio)	V			V																																										
RAM 1500	2015	RFH (Radio Frequency Hub)	V			V																																										
RAM 1500	2015	SCM (Steering Column Module)	V			V																																										
RAM 1500	2015	TCM (Transmission Control Module)	V			V																																										
RAM 1500	2015	WCM(Wireless Control Modules)	V			V																																										
RAM 1500	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 1500	2014	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAM 1500	2014	AMP (Audio)	V	V		V																																										
RAM 1500	2014	DDM (Drivers Door Module)	V	V	V	V																																										
RAM 1500	2014	DTCM (Drive Train Control Module)	V			V																																										
RAM 1500	2014	ESM (Electronic Shifter Module)	V			V																																										
RAM 1500	2014	HSM (Heated Seat Module)	V			V																																										
RAM 1500	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 1500	2014	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 1500	2014	PDM (Passenger Door Module)	V	V	V	V																																										
RAM 1500	2014	PTS (Park Assist Module)	V			V																																										
RAM 1500	2014	RADIO (Radio)	V	V		V																																										
RAM 1500	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 1500	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 1500	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAM 1500	2013	AMP (Audio)	V	V		V																																										
RAM 1500	2013	DDM (Drivers Door Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 1500	2013	DTCM (Drive Train Control Module)	V			V																																										
RAM 1500	2013	ESM (Electronic Shifter Module)	V			V																																										
RAM 1500	2013	HSM (Heated Seat Module)	V			V																																										
RAM 1500	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 1500	2013	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 1500	2013	PDM (Passenger Door Module)	V	V	V	V																																										
RAM 1500	2013	PTS (Park Assist Module)	V			V																																										
RAM 1500	2013	RADIO (Radio)	V	V		V																																										
RAM 1500	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 1500	2013	TPM (Tire Pressure Monitor)	V			V																																										
RAM 1500	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 1500	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAM 1500	2012	AMP (Audio)	V	V		V																																										
RAM 1500	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 1500	2012	DTCM (Drive Train Control Module)	V			V																																										
RAM 1500	2012	HFM (Hands Free Module)	V	V	V	V																																										
RAM 1500	2012	HSM (Heated Seat Module)	V			V																																										
RAM 1500	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 1500	2012	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 1500	2012	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 1500	2012	PTS (Park Assist Module)	V			V																																										
RAM 1500	2012	RADIO (Radio)	V	V		V																																										
RAM 1500	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 1500	2012	CGW (Central Gateway)	V	V	V	V																																										
RAM 1500	2012	TPM (Tire Pressure Monitor)	V			V																																										
RAM 1500	2012	VES3 (Vidio Entertainment System 3)	V			V																																										
RAM 1500	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 1500	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 1500	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAM 1500	2011	AMP (Audio)	V	V		V																																										
RAM 1500	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 1500	2011	DTCM (Drive Train Control Module)	V			V																																										
RAM 1500	2011	HFM (Hands Free Module)	V	V	V	V																																										
RAM 1500	2011	HSM (Heated Seat Module)	V			V																																										
RAM 1500	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 1500	2011	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 1500	2011	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 1500	2011	PTS (Park Assist Module)	V			V																																										
RAM 1500	2011	RADIO (Radio)	V	V		V																																										
RAM 1500	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 1500	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 1500	2011	CGW (Central Gateway)	V	V	V	V																																										
RAM 1500	2011	TPM (Tire Pressure Monitor)	V			V																																										
RAM 1500	2011	VES3 (Vidio Entertainment System 3)	V			V																																										
RAM 1500	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 1500	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 1500	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 1500	2010	AMP (Audio)	V	V		V																																										
RAM 1500	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 1500	2010	DTCM (Drive Train Control Module)	V			V																																										
RAM 1500	2010	HFM (Hands Free Module)	V	V	V	V																																										
RAM 1500	2010	HSM (Heated Seat Module)	V			V																																										
RAM 1500	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 1500	2010	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 1500	2010	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 1500	2010	PTS (Park Assist Module)	V			V																																										
RAM 1500	2010	RADIO (Radio)	V	V		V																																										
RAM 1500	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 1500	2010	CGW (Central Gateway)	V	V	V	V																																										
RAM 1500	2010	TPM (Tire Pressure Monitor)	V			V																																										
RAM 1500	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
RAM 1500	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 1500	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 1500	2009	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 1500	2009	AMP (Audio)	V	V		V																																										
RAM 1500	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 1500	2009	DTCM (Drive Train Control Module)	V			V																																										
RAM 1500	2009	HFM (Hands Free Module)	V	V	V	V																																										
RAM 1500	2009	HSM (Heated Seat Module)	V			V																																										
RAM 1500	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 1500	2009	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 1500	2009	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 1500	2009	PTS (Park Assist Module)	V			V																																										
RAM 1500	2009	RADIO (Radio)	V	V		V																																										
RAM 1500	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 1500	2009	CGW (Central Gateway)	V	V	V	V																																										
RAM 1500	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
RAM 1500	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 2500	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 2500	2016	ABS (Anti Lock Brake System)	V			V																																										
RAM 2500	2016	AMP (Audio)	V			V																																										
RAM 2500	2016	BCM (Body Control Module)	V			V																																										
RAM 2500	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM 2500	2016	CGW (Central Gateway)	V			V																																										
RAM 2500	2016	DDM (Drivers Door Module)	V			V																																										
RAM 2500	2016	DTCM (Drive Train Control Module)	V			V																																										
RAM 2500	2016	EDM (Electronic Damper Module)	V			V																																										
RAM 2500	2016	EPS (Electric Power Steering)	V			V																																										
RAM 2500	2016	ESM (Electronic Shifter Module)	V			V																																										
RAM 2500	2016	FDCM/AWD (Final Drive Control / All Wheel Drive)	V			V																																										
RAM 2500	2016	HSM (Heated Seat Module)	V			V																																										
RAM 2500	2016	HVAC (Heat Vent A/C)	V			V																																										
RAM 2500	2016	ICS (Integrated Center Stack)	V			V																																										
RAM 2500	2016	IPC (Instrument Panel Cluster)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 2500	2016	MSMD (Memory Seet Module)	V			V																																										
RAM 2500	2016	ORC (Occupant Restraint Control)	V			V																																										
RAM 2500	2016	PDM (Passenger Door Module)	V			V																																										
RAM 2500	2016	PTS (Park Assist Module)	V			V																																										
RAM 2500	2016	RADIO (Radio)	V			V																																										
RAM 2500	2016	RFH (Radio Frequency Hub)	V			V																																										
RAM 2500	2016	SCM (Steering Column Module)	V			V																																										
RAM 2500	2016	TCM (Transmission Control Module)	V			V																																										
RAM 2500	2016	WCM(Wireless Control Modules)	V			V																																										
RAM 2500	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 2500	2015	ABS (Anti Lock Brake System)	V			V																																										
RAM 2500	2015	AMP (Audio)	V			V																																										
RAM 2500	2015	BCM (Body Control Module)	V			V																																										
RAM 2500	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM 2500	2015	CGW (Central Gateway)	V			V																																										
RAM 2500	2015	DDM (Drivers Door Module)	V			V																																										
RAM 2500	2015	DTCM (Drive Train Control Module)	V			V																																										
RAM 2500	2015	EDM (Electronic Damper Module)	V			V																																										
RAM 2500	2015	EPS (Electric Power Steering)	V			V																																										
RAM 2500	2015	ESM (Electronic Shifter Module)	V			V																																										
RAM 2500	2015	FDCM/AWD (Final Drive Control / All Wheel Drive)	V			V																																										
RAM 2500	2015	HSM (Heated Seat Module)	V			V																																										
RAM 2500	2015	HVAC (Heat Vent A/C)	V			V																																										
RAM 2500	2015	ICS (Integrated Center Stack)	V			V																																										
RAM 2500	2015	IPC (Instrument Panel Cluster)	V			V																																										
RAM 2500	2015	MSMD (Memory Seet Module)	V			V																																										
RAM 2500	2015	ORC (Occupant Restraint Control)	V			V																																										
RAM 2500	2015	PDM (Passenger Door Module)	V			V																																										
RAM 2500	2015	PTS (Park Assist Module)	V			V																																										
RAM 2500	2015	RADIO (Radio)	V			V																																										
RAM 2500	2015	RFH (Radio Frequency Hub)	V			V																																										
RAM 2500	2015	SCM (Steering Column Module)	V			V																																										
RAM 2500	2015	TCM (Transmission Control Module)	V			V																																										
RAM 2500	2015	WCM(Wireless Control Modules)	V			V																																										
RAM 2500	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 2500	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V	
RAM 2500	2014	AMP (Audio)	V	V		V																																										
RAM 2500	2014	DDM (Drivers Door Module)	V	V	V	V																																										
RAM 2500	2014	DTCM (Drive Train Control Module)	V			V																																										
RAM 2500	2014	HSM (Heated Seat Module)	V			V																																										
RAM 2500	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 2500	2014	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 2500	2014	PDM (Passenger Door Module)	V	V	V	V																																										
RAM 2500	2014	PTS (Park Assist Module)	V			V																																										
RAM 2500	2014	RADIO (Radio)	V	V		V																																										
RAM 2500	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 2500	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 2500	2013	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 2500	2013	AMP (Audio)	V	V		V																																										
RAM 2500	2013	DDM (Drivers Door Module)	V	V	V	V																																										
RAM 2500	2013	DTCM (Drive Train Control Module)	V			V																																										
RAM 2500	2013	HSM (Heated Seat Module)	V			V																																										
RAM 2500	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 2500	2013	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 2500	2013	PDM (Passenger Door Module)	V	V	V	V																																										
RAM 2500	2013	PTS (Park Assist Module)	V			V																																										
RAM 2500	2013	RADIO (Radio)	V	V		V																																										
RAM 2500	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 2500	2013	TPM (Tire Pressure Monitor)	V			V																																										
RAM 2500	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 2500	2012	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 2500	2012	AMP (Audio)	V	V		V																																										
RAM 2500	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 2500	2012	DTCM (Drive Train Control Module)	V			V																																										
RAM 2500	2012	HFM (Hands Free Module)	V	V	V	V																																										
RAM 2500	2012	HSM (Heated Seat Module)	V			V																																										
RAM 2500	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 2500	2012	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 2500	2012	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 2500	2012	PTS (Park Assist Module)	V			V																																										
RAM 2500	2012	RADIO (Radio)	V	V		V																																										
RAM 2500	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 2500	2012	CGW (Central Gateway)	V	V	V	V																																										
RAM 2500	2012	TPM (Tire Pressure Monitor)	V			V																																										
RAM 2500	2012	VES3 (Vidio Entertainment System 3)	V			V																																										
RAM 2500	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 2500	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 2500	2011	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 2500	2011	AMP (Audio)	V	V		V																																										
RAM 2500	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 2500	2011	DTCM (Drive Train Control Module)	V			V																																										
RAM 2500	2011	HFM (Hands Free Module)	V	V	V	V																																										
RAM 2500	2011	HSM (Heated Seat Module)	V			V																																										
RAM 2500	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 2500	2011	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 2500	2011	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 2500	2011	PTS (Park Assist Module)	V			V																																										
RAM 2500	2011	RADIO (Radio)	V	V		V																																										
RAM 2500	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 2500	2011	CGW (Central Gateway)	V	V	V	V																																										
RAM 2500	2011	TPM (Tire Pressure Monitor)	V			V																																										
RAM 2500	2011	VES3 (Vidio Entertainment System 3)	V			V																																										
RAM 2500	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 2500	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 2500	2010	ABS (Anti Lock Brake System)	V	V	V	V																																					V	V	V	V
RAM 2500	2010	AMP (Audio)	V	V		V																																										
RAM 2500	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 2500	2010	DTCM (Drive Train Control Module)	V			V																																										
RAM 2500	2010	HFM (Hands Free Module)	V	V	V	V																																										
RAM 2500	2010	HSM (Heated Seat Module)	V			V																																										
RAM 2500	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 2500	2010	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 2500	2010	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 2500	2010	PTS (Park Assist Module)	V			V																																										
RAM 2500	2010	RADIO (Radio)	V	V		V																																										
RAM 2500	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 2500	2010	CGW (Central Gateway)	V	V	V	V																																										
RAM 2500	2010	TPM (Tire Pressure Monitor)	V			V																																										
RAM 2500	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
RAM 2500	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 3500 PICKUP	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 3500 PICKUP	2016	ABS (Anti Lock Brake System)	V			V																																										
RAM 3500 PICKUP	2016	AMP (Audio)	V			V																																										
RAM 3500 PICKUP	2016	BCM (Body Control Module)	V			V																																										
RAM 3500 PICKUP	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM 3500 PICKUP	2016	CGW (Central Gateway)	V			V																																										
RAM 3500 PICKUP	2016	DDM (Drivers Door Module)	V			V																																										
RAM 3500 PICKUP	2016	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 PICKUP	2016	EDM (Electronic Damper Module)	V			V																																										
RAM 3500 PICKUP	2016	EPS (Electric Power Steering)	V			V																																										
RAM 3500 PICKUP	2016	ESM (Electronic Shifter Module)	V			V																																										
RAM 3500 PICKUP	2016	HSM (Heated Seat Module)	V			V																																										
RAM 3500 PICKUP	2016	HVAC (Heat Vent A/C)	V			V																																										
RAM 3500 PICKUP	2016	ICS (Integrated Center Stack)	V			V																																										
RAM 3500 PICKUP	2016	IPC (Instrument Panel Cluster)	V			V																																										
RAM 3500 PICKUP	2016	MSMD (Memory Seet Module)	V			V																																										
RAM 3500 PICKUP	2016	ORC (Occupant Restraint Control)	V			V																																										
RAM 3500 PICKUP	2016	PDM (Passenger Door Module)	V			V																																										
RAM 3500 PICKUP	2016	PTS (Park Assist Module)	V			V																																										
RAM 3500 PICKUP	2016	RADIO (Radio)	V			V																																										
RAM 3500 PICKUP	2016	RFH (Radio Frequency Hub)	V			V																																										
RAM 3500 PICKUP	2016	SCM (Steering Column Module)	V			V																																										
RAM 3500 PICKUP	2016	TCM (Transmission Control Module)	V			V																																										
RAM 3500 PICKUP	2016	WCM(Wireless Control Modules)	V			V																																										
RAM 3500 PICKUP	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 3500 PICKUP	2015	ABS (Anti Lock Brake System)	V			V																																										
RAM 3500 PICKUP	2015	AMP (Audio)	V			V																																										
RAM 3500 PICKUP	2015	BCM (Body Control Module)	V			V																																										
RAM 3500 PICKUP	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM 3500 PICKUP	2015	CGW (Central Gateway)	V			V																																										
RAM 3500 PICKUP	2015	DDM (Drivers Door Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 3500 PICKUP	2015	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 PICKUP	2015	EDM (Electronic Damper Module)	V			V																																										
RAM 3500 PICKUP	2015	EPS (Electric Power Steering)	V			V																																										
RAM 3500 PICKUP	2015	ESM (Electronic Shifter Module)	V			V																																										
RAM 3500 PICKUP	2015	HSM (Heated Seat Module)	V			V																																										
RAM 3500 PICKUP	2015	HVAC (Heat Vent A/C)	V			V																																										
RAM 3500 PICKUP	2015	ICS (Integrated Center Stack)	V			V																																										
RAM 3500 PICKUP	2015	IPC (Instrument Panel Cluster)	V			V																																										
RAM 3500 PICKUP	2015	MSMD (Memory Seet Module)	V			V																																										
RAM 3500 PICKUP	2015	ORC (Occupant Restraint Control)	V			V																																										
RAM 3500 PICKUP	2015	PDM (Passenger Door Module)	V			V																																										
RAM 3500 PICKUP	2015	PTS (Park Assist Module)	V			V																																										
RAM 3500 PICKUP	2015	RADIO (Radio)	V			V																																										
RAM 3500 PICKUP	2015	RFH (Radio Frequency Hub)	V			V																																										
RAM 3500 PICKUP	2015	SCM (Steering Column Module)	V			V																																										
RAM 3500 PICKUP	2015	TCM (Transmission Control Module)	V			V																																										
RAM 3500 PICKUP	2015	WCM(Wireless Control Modules)	V			V																																										
RAM 3500 PICKUP	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 3500 PICKUP	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 3500 PICKUP	2014	AMP (Audio)	V	V		V																																										
RAM 3500 PICKUP	2014	DDM (Drivers Door Module)	V	V	V	V																																										
RAM 3500 PICKUP	2014	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 PICKUP	2014	HSM (Heated Seat Module)	V			V																																										
RAM 3500 PICKUP	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 3500 PICKUP	2014	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 3500 PICKUP	2014	PDM (Passenger Door Module)	V	V	V	V																																										
RAM 3500 PICKUP	2014	PTS (Park Assist Module)	V			V																																										
RAM 3500 PICKUP	2014	RADIO (Radio)	V	V		V																																										
RAM 3500 PICKUP	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 3500 PICKUP	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 3500 PICKUP	2013	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 3500 PICKUP	2013	AMP (Audio)	V	V		V																																										
RAM 3500 PICKUP	2013	DDM (Drivers Door Module)	V	V	V	V																																										
RAM 3500 PICKUP	2013	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 PICKUP	2013	HSM (Heated Seat Module)	V			V																																										
RAM 3500 PICKUP	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 3500 PICKUP	2013	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 3500 PICKUP	2013	PDM (Passenger Door Module)	V	V	V	V																																										
RAM 3500 PICKUP	2013	PTS (Park Assist Module)	V			V																																										
RAM 3500 PICKUP	2013	RADIO (Radio)	V	V		V																																										
RAM 3500 PICKUP	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 3500 PICKUP	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 3500 PICKUP	2012	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 3500 PICKUP	2012	AMP (Audio)	V	V		V																																										
RAM 3500 PICKUP	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 3500 PICKUP	2012	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 PICKUP	2012	HFM (Hands Free Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 3500 PICKUP	2012	HSM (Heated Seat Module)	V			V																																										
RAM 3500 PICKUP	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 3500 PICKUP	2012	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 3500 PICKUP	2012	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 3500 PICKUP	2012	PTS (Park Assist Module)	V			V																																										
RAM 3500 PICKUP	2012	RADIO (Radio)	V	V		V																																										
RAM 3500 PICKUP	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 3500 PICKUP	2012	CGW (Central Gateway)	V	V	V	V																																										
RAM 3500 PICKUP	2012	VES3 (Vidio Entertainment System 3)	V			V																																										
RAM 3500 PICKUP	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 3500 PICKUP	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
RAM 3500 PICKUP	2011	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 3500 PICKUP	2011	AMP (Audio)	V	V		V																																										
RAM 3500 PICKUP	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 3500 PICKUP	2011	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 PICKUP	2011	HFM (Hands Free Module)	V	V	V	V																																										
RAM 3500 PICKUP	2011	HSM (Heated Seat Module)	V			V																																										
RAM 3500 PICKUP	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 3500 PICKUP	2011	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 3500 PICKUP	2011	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 3500 PICKUP	2011	PTS (Park Assist Module)	V			V																																										
RAM 3500 PICKUP	2011	RADIO (Radio)	V	V		V																																										
RAM 3500 PICKUP	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 3500 PICKUP	2011	CGW (Central Gateway)	V	V	V	V																																										
RAM 3500 PICKUP	2011	VES3 (Vidio Entertainment System 3)	V			V																																										
RAM 3500 PICKUP	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 3500 PICKUP	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
RAM 3500 PICKUP	2010	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 3500 PICKUP	2010	AMP (Audio)	V	V		V																																										
RAM 3500 PICKUP	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 3500 PICKUP	2010	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 PICKUP	2010	HFM (Hands Free Module)	V	V	V	V																																										
RAM 3500 PICKUP	2010	HSM (Heated Seat Module)	V			V																																										
RAM 3500 PICKUP	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 3500 PICKUP	2010	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 3500 PICKUP	2010	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 3500 PICKUP	2010	PTS (Park Assist Module)	V			V																																										
RAM 3500 PICKUP	2010	RADIO (Radio)	V	V		V																																										
RAM 3500 PICKUP	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 3500 PICKUP	2010	CGW (Central Gateway)	V	V	V	V																																										
RAM 3500 PICKUP	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
RAM 3500 PICKUP	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 3500 Cab Chassis	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
RAM 3500 Cab Chassis	2016	ABS (Anti Lock Brake System)	V			V																																										
RAM 3500 Cab Chassis	2016	AMP (Audio)	V			V																																										
RAM 3500 Cab Chassis	2016	BCM (Body Control Module)	V			V																																										
RAM 3500 Cab Chassis	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 3500 Cab Chassis	2016	CGW (Central Gateway)	V			V																																										
RAM 3500 Cab Chassis	2016	DDM (Drivers Door Module)	V			V																																										
RAM 3500 Cab Chassis	2016	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 Cab Chassis	2016	EDM (Electronic Damper Module)	V			V																																										
RAM 3500 Cab Chassis	2016	EPS (Electric Power Steering)	V			V																																										
RAM 3500 Cab Chassis	2016	ESM (Electronic Shifter Module)	V			V																																										
RAM 3500 Cab Chassis	2016	HSM (Heated Seat Module)	V			V																																										
RAM 3500 Cab Chassis	2016	HVAC (Heat Vent A/C)	V			V																																										
RAM 3500 Cab Chassis	2016	ICS (Integrated Center Stack)	V			V																																										
RAM 3500 Cab Chassis	2016	IPC (Instrument Panel Cluster)	V			V																																										
RAM 3500 Cab Chassis	2016	MSMD (Memory Seet Module)	V			V																																										
RAM 3500 Cab Chassis	2016	ORC (Occupant Restraint Control)	V			V																																										
RAM 3500 Cab Chassis	2016	PDM (Passenger Door Module)	V			V																																										
RAM 3500 Cab Chassis	2016	PTS (Park Assist Module)	V			V																																										
RAM 3500 Cab Chassis	2016	RADIO (Radio)	V			V																																										
RAM 3500 Cab Chassis	2016	RFH (Radio Frequency Hub)	V			V																																										
RAM 3500 Cab Chassis	2016	SCM (Steering Column Module)	V			V																																										
RAM 3500 Cab Chassis	2016	TCM (Transmission Control Module)	V			V																																										
RAM 3500 Cab Chassis	2016	WCM(Wireless Control Modules)	V			V																																										
RAM 3500 Cab Chassis	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 3500 Cab Chassis	2015	ABS (Anti Lock Brake System)	V			V																																										
RAM 3500 Cab Chassis	2015	AMP (Audio)	V			V																																										
RAM 3500 Cab Chassis	2015	BCM (Body Control Module)	V			V																																										
RAM 3500 Cab Chassis	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM 3500 Cab Chassis	2015	CGW (Central Gateway)	V			V																																										
RAM 3500 Cab Chassis	2015	DDM (Drivers Door Module)	V			V																																										
RAM 3500 Cab Chassis	2015	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 Cab Chassis	2015	EDM (Electronic Damper Module)	V			V																																										
RAM 3500 Cab Chassis	2015	EPS (Electric Power Steering)	V			V																																										
RAM 3500 Cab Chassis	2015	ESM (Electronic Shifter Module)	V			V																																										
RAM 3500 Cab Chassis	2015	HSM (Heated Seat Module)	V			V																																										
RAM 3500 Cab Chassis	2015	HVAC (Heat Vent A/C)	V			V																																										
RAM 3500 Cab Chassis	2015	ICS (Integrated Center Stack)	V			V																																										
RAM 3500 Cab Chassis	2015	IPC (Instrument Panel Cluster)	V			V																																										
RAM 3500 Cab Chassis	2015	MSMD (Memory Seet Module)	V			V																																										
RAM 3500 Cab Chassis	2015	ORC (Occupant Restraint Control)	V			V																																										
RAM 3500 Cab Chassis	2015	PDM (Passenger Door Module)	V			V																																										
RAM 3500 Cab Chassis	2015	PTS (Park Assist Module)	V			V																																										
RAM 3500 Cab Chassis	2015	RADIO (Radio)	V			V																																										
RAM 3500 Cab Chassis	2015	RFH (Radio Frequency Hub)	V			V																																										
RAM 3500 Cab Chassis	2015	SCM (Steering Column Module)	V			V																																										
RAM 3500 Cab Chassis	2015	TCM (Transmission Control Module)	V			V																																										
RAM 3500 Cab Chassis	2015	WCM(Wireless Control Modules)	V			V																																										
RAM 3500 Cab Chassis	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 3500 Cab Chassis	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 3500 Cab Chassis	2014	AMP (Audio)	V	V		V																																										
RAM 3500 Cab Chassis	2014	DDM (Drivers Door Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 3500 Cab Chassis	2014	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 Cab Chassis	2014	HSM (Heated Seat Module)	V			V																																										
RAM 3500 Cab Chassis	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 3500 Cab Chassis	2014	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 3500 Cab Chassis	2014	PDM (Passenger Door Module)	V	V	V	V																																										
RAM 3500 Cab Chassis	2014	PTS (Park Assist Module)	V			V																																										
RAM 3500 Cab Chassis	2014	RADIO (Radio)	V	V		V																																										
RAM 3500 Cab Chassis	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 3500 Cab Chassis	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
RAM 3500 Cab Chassis	2013	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 3500 Cab Chassis	2013	AMP (Audio)	V	V		V																																										
RAM 3500 Cab Chassis	2013	DDM (Drivers Door Module)	V	V	V	V																																										
RAM 3500 Cab Chassis	2013	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 Cab Chassis	2013	HSM (Heated Seat Module)	V			V																																										
RAM 3500 Cab Chassis	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 3500 Cab Chassis	2013	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 3500 Cab Chassis	2013	PDM (Passenger Door Module)	V	V	V	V																																										
RAM 3500 Cab Chassis	2013	PTS (Park Assist Module)	V			V																																										
RAM 3500 Cab Chassis	2013	RADIO (Radio)	V	V		V																																										
RAM 3500 Cab Chassis	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 3500 Cab Chassis	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
RAM 3500 Cab Chassis	2012	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 3500 Cab Chassis	2012	AMP (Audio)	V	V		V																																										
RAM 3500 Cab Chassis	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 3500 Cab Chassis	2012	DDM (Drivers Door Module)	V	V	V	V																																										
RAM 3500 Cab Chassis	2012	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 Cab Chassis	2012	HFM (Hands Free Module)	V	V	V	V																																										
RAM 3500 Cab Chassis	2012	HSM (Heated Seat Module)	V			V																																										
RAM 3500 Cab Chassis	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 3500 Cab Chassis	2012	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 3500 Cab Chassis	2012	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 3500 Cab Chassis	2012	RADIO (Radio)	V	V		V																																										
RAM 3500 Cab Chassis	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 3500 Cab Chassis	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 3500 Cab Chassis	2012	CGW (Central Gateway)	V	V	V	V																																										
RAM 3500 Cab Chassis	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 3500 Cab Chassis	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
RAM 3500 Cab Chassis	2011	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 3500 Cab Chassis	2011	AMP (Audio)	V	V		V																																										
RAM 3500 Cab Chassis	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 3500 Cab Chassis	2011	DDM (Drivers Door Module)	V	V	V	V																																										
RAM 3500 Cab Chassis	2011	DTCM (Drive Train Control Module)	V			V																																										
RAM 3500 Cab Chassis	2011	HFM (Hands Free Module)	V	V	V	V																																										
RAM 3500 Cab Chassis	2011	HSM (Heated Seat Module)	V			V																																										
RAM 3500 Cab Chassis	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 3500 Cab Chassis	2011	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 3500 Cab Chassis	2011	ORC (Occupant Restraint Control)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 3500 Cab Chassis	2011	RADIO (Radio)	V	V		V																																										
RAM 3500 Cab Chassis	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 3500 Cab Chassis	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 3500 Cab Chassis	2011	CGW (Central Gateway)	V	V	V	V																																										
RAM 3500 Cab Chassis	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 4500	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 4500	2016	ABS (Anti Lock Brake System)	V			V																																										
RAM 4500	2016	AMP (Audio)	V			V																																										
RAM 4500	2016	BCM (Body Control Module)	V			V																																										
RAM 4500	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM 4500	2016	CGW (Central Gateway)	V			V																																										
RAM 4500	2016	DDM (Drivers Door Module)	V			V																																										
RAM 4500	2016	DTCM (Drive Train Control Module)	V			V																																										
RAM 4500	2016	EDM (Electronic Damper Module)	V			V																																										
RAM 4500	2016	EPS (Electric Power Steering)	V			V																																										
RAM 4500	2016	ESM (Electronic Shifter Module)	V			V																																										
RAM 4500	2016	HSM (Heated Seat Module)	V			V																																										
RAM 4500	2016	HVAC (Heat Vent A/C)	V			V																																										
RAM 4500	2016	ICS (Integrated Center Stack)	V			V																																										
RAM 4500	2016	IPC (Instrument Panel Cluster)	V			V																																										
RAM 4500	2016	MSMD (Memory Seet Module)	V			V																																										
RAM 4500	2016	ORC (Occupant Restraint Control)	V			V																																										
RAM 4500	2016	PDM (Passenger Door Module)	V			V																																										
RAM 4500	2016	PTS (Park Assist Module)	V			V																																										
RAM 4500	2016	RADIO (Radio)	V			V																																										
RAM 4500	2016	RFH (Radio Frequency Hub)	V			V																																										
RAM 4500	2016	SCM (Steering Column Module)	V			V																																										
RAM 4500	2016	TCM (Transmission Control Module)	V			V																																										
RAM 4500	2016	WCM(Wireless Control Modules)	V			V																																										
RAM 4500	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 4500	2015	ABS (Anti Lock Brake System)	V			V																																										
RAM 4500	2015	AMP (Audio)	V			V																																										
RAM 4500	2015	BCM (Body Control Module)	V			V																																										
RAM 4500	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM 4500	2015	CGW (Central Gateway)	V			V																																										
RAM 4500	2015	DDM (Drivers Door Module)	V			V																																										
RAM 4500	2015	DTCM (Drive Train Control Module)	V			V																																										
RAM 4500	2015	EDM (Electronic Damper Module)	V			V																																										
RAM 4500	2015	EPS (Electric Power Steering)	V			V																																										
RAM 4500	2015	ESM (Electronic Shifter Module)	V			V																																										
RAM 4500	2015	HSM (Heated Seat Module)	V			V																																										
RAM 4500	2015	HVAC (Heat Vent A/C)	V			V																																										
RAM 4500	2015	ICS (Integrated Center Stack)	V			V																																										
RAM 4500	2015	IPC (Instrument Panel Cluster)	V			V																																										
RAM 4500	2015	MSMD (Memory Seet Module)	V			V																																										
RAM 4500	2015	ORC (Occupant Restraint Control)	V			V																																										
RAM 4500	2015	PDM (Passenger Door Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 4500	2015	PTS (Park Assist Module)	V			V																																										
RAM 4500	2015	RADIO (Radio)	V			V																																										
RAM 4500	2015	RFH (Radio Frequency Hub)	V			V																																										
RAM 4500	2015	SCM (Steering Column Module)	V			V																																										
RAM 4500	2015	TCM (Transmission Control Module)	V			V																																										
RAM 4500	2015	WCM(Wireless Control Modules)	V			V																																										
RAM 4500	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 4500	2014	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAM 4500	2014	AMP (Audio)	V	V		V																																										
RAM 4500	2014	DDM (Drivers Door Module)	V	V	V	V																																										
RAM 4500	2014	DTCM (Drive Train Control Module)	V			V																																										
RAM 4500	2014	HSM (Heated Seat Module)	V			V																																										
RAM 4500	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 4500	2014	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 4500	2014	PDM (Passenger Door Module)	V	V	V	V																																										
RAM 4500	2014	PTS (Park Assist Module)	V			V																																										
RAM 4500	2014	RADIO (Radio)	V	V		V																																										
RAM 4500	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 4500	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 4500	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAM 4500	2013	AMP (Audio)	V	V		V																																										
RAM 4500	2013	DDM (Drivers Door Module)	V	V	V	V																																										
RAM 4500	2013	DTCM (Drive Train Control Module)	V			V																																										
RAM 4500	2013	HSM (Heated Seat Module)	V			V																																										
RAM 4500	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 4500	2013	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 4500	2013	PDM (Passenger Door Module)	V	V	V	V																																										
RAM 4500	2013	PTS (Park Assist Module)	V			V																																										
RAM 4500	2013	RADIO (Radio)	V	V		V																																										
RAM 4500	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 4500	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 4500	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAM 4500	2012	AMP (Audio)	V	V		V																																										
RAM 4500	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 4500	2012	DTCM (Drive Train Control Module)	V			V																																										
RAM 4500	2012	HFM (Hands Free Module)	V	V	V	V																																										
RAM 4500	2012	HSM (Heated Seat Module)	V			V																																										
RAM 4500	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 4500	2012	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 4500	2012	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 4500	2012	RADIO (Radio)	V	V		V																																										
RAM 4500	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 4500	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 4500	2012	CGW (Central Gateway)	V	V	V	V																																										
RAM 4500	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 4500	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 4500	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 4500	2011	AMP (Audio)	V	V		V																																										
RAM 4500	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 4500	2011	DTCM (Drive Train Control Module)	V			V																																										
RAM 4500	2011	HFM (Hands Free Module)	V	V	V	V																																										
RAM 4500	2011	HSM (Heated Seat Module)	V			V																																										
RAM 4500	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 4500	2011	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 4500	2011	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 4500	2011	RADIO (Radio)	V	V		V																																										
RAM 4500	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 4500	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 4500	2011	CGW (Central Gateway)	V	V	V	V																																										
RAM 4500	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 5500	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 5500	2016	ABS (Anti Lock Brake System)	V			V																																										
RAM 5500	2016	AMP (Audio)	V			V																																										
RAM 5500	2016	BCM (Body Control Module)	V			V																																										
RAM 5500	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM 5500	2016	CGW (Central Gateway)	V			V																																										
RAM 5500	2016	DDM (Drivers Door Module)	V			V																																										
RAM 5500	2016	DTCM (Drive Train Control Module)	V			V																																										
RAM 5500	2016	EDM (Electronic Damper Module)	V			V																																										
RAM 5500	2016	EPS (Electric Power Steering)	V			V																																										
RAM 5500	2016	ESM (Electronic Shifter Module)	V			V																																										
RAM 5500	2016	HSM (Heated Seat Module)	V			V																																										
RAM 5500	2016	HVAC (Heat Vent A/C)	V			V																																										
RAM 5500	2016	ICS (Integrated Center Stack)	V			V																																										
RAM 5500	2016	IPC (Instrument Panel Cluster)	V			V																																										
RAM 5500	2016	MSMD (Memory Seet Module)	V			V																																										
RAM 5500	2016	ORC (Occupant Restraint Control)	V			V																																										
RAM 5500	2016	PDM (Passenger Door Module)	V			V																																										
RAM 5500	2016	PTS (Park Assist Module)	V			V																																										
RAM 5500	2016	RADIO (Radio)	V			V																																										
RAM 5500	2016	RFH (Radio Frequency Hub)	V			V																																										
RAM 5500	2016	SCM (Steering Column Module)	V			V																																										
RAM 5500	2016	TCM (Transmission Control Module)	V			V																																										
RAM 5500	2016	WCM(Wireless Control Modules)	V			V																																										
RAM 5500	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 5500	2015	ABS (Anti Lock Brake System)	V			V																																										
RAM 5500	2015	AMP (Audio)	V			V																																										
RAM 5500	2015	BCM (Body Control Module)	V			V																																										
RAM 5500	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM 5500	2015	CGW (Central Gateway)	V			V																																										
RAM 5500	2015	DDM (Drivers Door Module)	V			V																																										
RAM 5500	2015	DTCM (Drive Train Control Module)	V			V																																										
RAM 5500	2015	EDM (Electronic Damper Module)	V			V																																										
RAM 5500	2015	EPS (Electric Power Steering)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 5500	2015	ESM (Electronic Shifter Module)	V			V																																										
RAM 5500	2015	HSM (Heated Seat Module)	V			V																																										
RAM 5500	2015	HVAC (Heat Vent A/C)	V			V																																										
RAM 5500	2015	ICS (Integrated Center Stack)	V			V																																										
RAM 5500	2015	IPC (Instrument Panel Cluster)	V			V																																										
RAM 5500	2015	MSMD (Memory Seet Module)	V			V																																										
RAM 5500	2015	ORC (Occupant Restraint Control)	V			V																																										
RAM 5500	2015	PDM (Passenger Door Module)	V			V																																										
RAM 5500	2015	PTS (Park Assist Module)	V			V																																										
RAM 5500	2015	RADIO (Radio)	V			V																																										
RAM 5500	2015	RFH (Radio Frequency Hub)	V			V																																										
RAM 5500	2015	SCM (Steering Column Module)	V			V																																										
RAM 5500	2015	TCM (Transmission Control Module)	V			V																																										
RAM 5500	2015	WCM(Wireless Control Modules)	V			V																																										
RAM 5500	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 5500	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 5500	2014	AMP (Audio)	V	V		V																																										
RAM 5500	2014	DDM (Drivers Door Module)	V	V	V	V																																										
RAM 5500	2014	DTCM (Drive Train Control Module)	V			V																																										
RAM 5500	2014	HSM (Heated Seat Module)	V			V																																										
RAM 5500	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 5500	2014	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 5500	2014	PDM (Passenger Door Module)	V	V	V	V																																										
RAM 5500	2014	PTS (Park Assist Module)	V			V																																										
RAM 5500	2014	RADIO (Radio)	V	V		V																																										
RAM 5500	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 5500	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 5500	2013	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 5500	2013	AMP (Audio)	V	V		V																																										
RAM 5500	2013	DDM (Drivers Door Module)	V	V	V	V																																										
RAM 5500	2013	DTCM (Drive Train Control Module)	V			V																																										
RAM 5500	2013	HSM (Heated Seat Module)	V			V																																										
RAM 5500	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 5500	2013	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 5500	2013	PDM (Passenger Door Module)	V	V	V	V																																										
RAM 5500	2013	PTS (Park Assist Module)	V			V																																										
RAM 5500	2013	RADIO (Radio)	V	V		V																																										
RAM 5500	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 5500	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 5500	2012	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM 5500	2012	AMP (Audio)	V	V		V																																										
RAM 5500	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 5500	2012	DTCM (Drive Train Control Module)	V			V																																										
RAM 5500	2012	HFM (Hands Free Module)	V	V	V	V																																										
RAM 5500	2012	HSM (Heated Seat Module)	V			V																																										
RAM 5500	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 5500	2012	MSMD (Memory Seet Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM 5500	2012	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 5500	2012	RADIO (Radio)	V	V		V																																										
RAM 5500	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 5500	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 5500	2012	CGW (Central Gateway)	V	V	V	V																																										
RAM 5500	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM 5500	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM 5500	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAM 5500	2011	AMP (Audio)	V	V		V																																										
RAM 5500	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAM 5500	2011	DTCM (Drive Train Control Module)	V			V																																										
RAM 5500	2011	HFM (Hands Free Module)	V	V	V	V																																										
RAM 5500	2011	HSM (Heated Seat Module)	V			V																																										
RAM 5500	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM 5500	2011	MSMD (Memory Seet Module)	V	V	V	V																																										
RAM 5500	2011	ORC (Occupant Restraint Control)	V	V		V																																										
RAM 5500	2011	RADIO (Radio)	V	V		V																																										
RAM 5500	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM 5500	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM 5500	2011	CGW (Central Gateway)	V	V	V	V																																										
RAM 5500	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
RAM (Mexico)	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM (Mexico)	2016	ABS (Anti Lock Brake System)	V			V																																										
RAM (Mexico)	2016	AMP (Audio)	V			V																																										
RAM (Mexico)	2016	BCM (Body Control Module)	V			V																																										
RAM (Mexico)	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM (Mexico)	2016	CGW (Central Gateway)	V			V																																										
RAM (Mexico)	2016	DDM (Drivers Door Module)	V			V																																										
RAM (Mexico)	2016	DTCM (Drive Train Control Module)	V			V																																										
RAM (Mexico)	2016	EDM (Electronic Damper Module)	V			V																																										
RAM (Mexico)	2016	EPS (Electric Power Steering)	V			V																																										
RAM (Mexico)	2016	ESM (Electronic Shifter Module)	V			V																																										
RAM (Mexico)	2016	HSM (Heated Seat Module)	V			V																																										
RAM (Mexico)	2016	HVAC (Heat Vent A/C)	V			V																																										
RAM (Mexico)	2016	ICS (Integrated Center Stack)	V			V																																										
RAM (Mexico)	2016	IPC (Instrument Panel Cluster)	V			V																																										
RAM (Mexico)	2016	MSMD (Memory Seet Module)	V			V																																										
RAM (Mexico)	2016	ORC (Occupant Restraint Control)	V			V																																										
RAM (Mexico)	2016	PDM (Passenger Door Module)	V			V																																										
RAM (Mexico)	2016	PTS (Park Assist Module)	V			V																																										
RAM (Mexico)	2016	RADIO (Radio)	V			V																																										
RAM (Mexico)	2016	RFH (Radio Frequency Hub)	V			V																																										
RAM (Mexico)	2016	SCM (Steering Column Module)	V			V																																										
RAM (Mexico)	2016	TCM (Transmission Control Module)	V			V																																										
RAM (Mexico)	2016	WCM(Wireless Control Modules)	V			V																																										
RAM (Mexico)	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM (Mexico)	2015	ABS (Anti Lock Brake System)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM (Mexico)	2015	AMP (Audio)	V			V																																										
RAM (Mexico)	2015	BCM (Body Control Module)	V			V																																										
RAM (Mexico)	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RAM (Mexico)	2015	CGW (Central Gateway)	V			V																																										
RAM (Mexico)	2015	DDM (Drivers Door Module)	V			V																																										
RAM (Mexico)	2015	DTCM (Drive Train Control Module)	V			V																																										
RAM (Mexico)	2015	EDM (Electronic Damper Module)	V			V																																										
RAM (Mexico)	2015	EPS (Electric Power Steering)	V			V																																										
RAM (Mexico)	2015	ESM (Electronic Shifter Module)	V			V																																										
RAM (Mexico)	2015	HSM (Heated Seat Module)	V			V																																										
RAM (Mexico)	2015	HVAC (Heat Vent A/C)	V			V																																										
RAM (Mexico)	2015	ICS (Integrated Center Stack)	V			V																																										
RAM (Mexico)	2015	IPC (Instrument Panel Cluster)	V			V																																										
RAM (Mexico)	2015	MSMD (Memory Seet Module)	V			V																																										
RAM (Mexico)	2015	ORC (Occupant Restraint Control)	V			V																																										
RAM (Mexico)	2015	PDM (Passenger Door Module)	V			V																																										
RAM (Mexico)	2015	PTS (Park Assist Module)	V			V																																										
RAM (Mexico)	2015	RADIO (Radio)	V			V																																										
RAM (Mexico)	2015	RFH (Radio Frequency Hub)	V			V																																										
RAM (Mexico)	2015	SCM (Steering Column Module)	V			V																																										
RAM (Mexico)	2015	TCM (Transmission Control Module)	V			V																																										
RAM (Mexico)	2015	WCM(Wireless Control Modules)	V			V																																										
RAM (Mexico)	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM (Mexico)	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM (Mexico)	2014	AMP (Audio)	V	V		V																																										
RAM (Mexico)	2014	DDM (Drivers Door Module)	V	V	V	V																																										
RAM (Mexico)	2014	DTCM (Drive Train Control Module)	V			V																																										
RAM (Mexico)	2014	ESM (Electronic Shifter Module)	V			V																																										
RAM (Mexico)	2014	HSM (Heated Seat Module)	V			V																																										
RAM (Mexico)	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM (Mexico)	2014	ORC (Occupant Restraint Control)	V	V		V																																										
RAM (Mexico)	2014	PDM (Passenger Door Module)	V	V	V	V																																										
RAM (Mexico)	2014	PTS (Park Assist Module)	V			V																																										
RAM (Mexico)	2014	RADIO (Radio)	V	V		V																																										
RAM (Mexico)	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAM (Mexico)	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAM (Mexico)	2013	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM (Mexico)	2013	AMP (Audio)	V	V		V																																										
RAM (Mexico)	2013	DDM (Drivers Door Module)	V	V	V	V																																										
RAM (Mexico)	2013	DTCM (Drive Train Control Module)	V			V																																										
RAM (Mexico)	2013	ESM (Electronic Shifter Module)	V			V																																										
RAM (Mexico)	2013	HSM (Heated Seat Module)	V			V																																										
RAM (Mexico)	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAM (Mexico)	2013	ORC (Occupant Restraint Control)	V	V		V																																										
RAM (Mexico)	2013	PDM (Passenger Door Module)	V	V	V	V																																										
RAM (Mexico)	2013	PTS (Park Assist Module)	V			V																																										
RAM (Mexico)	2013	RADIO (Radio)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM (Mexico)	2013	TCM (Transmission Control Module)	V	V	V	V	V																															V	V	V	V	V	V				
RAM (Mexico)	2013	TPM (Tire Pressure Monitor)	V			V																																									
RAM (Mexico)	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
RAM (Mexico)	2012	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM (Mexico)	2012	AMP (Audio)	V	V		V																																									
RAM (Mexico)	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																									
RAM (Mexico)	2012	DTCM (Drive Train Control Module)	V			V																																									
RAM (Mexico)	2012	HFM (Hands Free Module)	V	V	V	V																																									
RAM (Mexico)	2012	HSM (Heated Seat Module)	V			V																																									
RAM (Mexico)	2012	HVAC (Heat Vent A/C)	V	V	V	V																																									
RAM (Mexico)	2012	MSMD (Memory Seet Module)	V	V	V	V																																									
RAM (Mexico)	2012	ORC (Occupant Restraint Control)	V	V		V																																									
RAM (Mexico)	2012	PTS (Park Assist Module)	V			V																																									
RAM (Mexico)	2012	RADIO (Radio)	V	V		V																																									
RAM (Mexico)	2012	SAS (Steering Angle Sensor)	V	V	V	V																																									
RAM (Mexico)	2012	CGW (Central Gateway)	V	V	V	V																																									
RAM (Mexico)	2012	TPM (Tire Pressure Monitor)	V			V																																									
RAM (Mexico)	2012	VES3 (Vidio Entertainment System 3)	V			V																																									
RAM (Mexico)	2012	WCM(Wireless Control Modules)	V	V	V	V																																									
RAM (Mexico)	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
RAM (Mexico)	2011	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM (Mexico)	2011	AMP (Audio)	V	V		V																																									
RAM (Mexico)	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																									
RAM (Mexico)	2011	DTCM (Drive Train Control Module)	V			V																																									
RAM (Mexico)	2011	HFM (Hands Free Module)	V	V	V	V																																									
RAM (Mexico)	2011	HSM (Heated Seat Module)	V			V																																									
RAM (Mexico)	2011	HVAC (Heat Vent A/C)	V	V	V	V																																									
RAM (Mexico)	2011	MSMD (Memory Seet Module)	V	V	V	V																																									
RAM (Mexico)	2011	ORC (Occupant Restraint Control)	V	V		V																																									
RAM (Mexico)	2011	PTS (Park Assist Module)	V			V																																									
RAM (Mexico)	2011	RADIO (Radio)	V	V		V																																									
RAM (Mexico)	2011	SAS (Steering Angle Sensor)	V	V	V	V																																									
RAM (Mexico)	2011	CGW (Central Gateway)	V	V	V	V																																									
RAM (Mexico)	2011	TPM (Tire Pressure Monitor)	V			V																																									
RAM (Mexico)	2011	VES3 (Vidio Entertainment System 3)	V			V																																									
RAM (Mexico)	2011	WCM(Wireless Control Modules)	V	V	V	V																																									
RAM (Mexico)	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
RAM (Mexico)	2010	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
RAM (Mexico)	2010	AMP (Audio)	V	V		V																																									
RAM (Mexico)	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																									
RAM (Mexico)	2010	DTCM (Drive Train Control Module)	V			V																																									
RAM (Mexico)	2010	HFM (Hands Free Module)	V	V	V	V																																									
RAM (Mexico)	2010	HSM (Heated Seat Module)	V			V																																									
RAM (Mexico)	2010	HVAC (Heat Vent A/C)	V	V	V	V																																									
RAM (Mexico)	2010	MSMD (Memory Seet Module)	V	V	V	V																																									
RAM (Mexico)	2010	ORC (Occupant Restraint Control)	V	V		V																																									
RAM (Mexico)	2010	PTS (Park Assist Module)	V			V																																									

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAM (Mexico)	2010	RADIO (Radio)	V	V		V																																										
RAM (Mexico)	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
RAM (Mexico)	2010	CGW (Central Gateway)	V	V	V	V																																										
RAM (Mexico)	2010	TPM (Tire Pressure Monitor)	V			V																																										
RAM (Mexico)	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
RAM (Mexico)	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
DART	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DART	2016	ABS (Anti Lock Brake System)	V			V																																										
DART	2016	AMP (Audio)	V			V																																										
DART	2016	BCM (Body Control Module)	V			V																																										
DART	2016	FDCM/AWD (Final Drive Control / All Wheel Drive)	V			V																																										
DART	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
DART	2016	CGW (Central Gateway)	V			V																																										
DART	2016	EDM (Electronic Damper Module)	V			V																																										
DART	2016	EPS (Electric Power Steering)	V			V																																										
DART	2016	ESM (Electronic Shifter Module)	V			V																																										
DART	2016	HVAC (Heat Vent A/C)	V			V																																										
DART	2016	ICS (Integrated Center Stack)	V			V																																										
DART	2016	IPC (Instrument Panel Cluster)	V			V																																										
DART	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
DART	2016	OCM (Occupant Classification Module)	V			V																																										
DART	2016	ORC (Occupant Restraint Control)	V			V																																										
DART	2016	RADIO (Radio)	V			V																																										
DART	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
DART	2016	RFH (Radio Frequency Hub)	V			V																																										
DART	2016	SCM (Steering Column Module)	V			V																																										
DART	2016	TCM (Transmission Control Module)	V			V																																										
DART	2016	WCM(Wireless Control Modules)	V			V																																										
DART	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DART	2015	ABS (Anti Lock Brake System)	V			V																																										
DART	2015	AMP (Audio)	V			V																																										
DART	2015	BCM (Body Control Module)	V			V																																										
DART	2015	FDCM/AWD (Final Drive Control / All Wheel Drive)	V			V																																										
DART	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
DART	2015	CGW (Central Gateway)	V			V																																										
DART	2015	EDM (Electronic Damper Module)	V			V																																										
DART	2015	EPS (Electric Power Steering)	V			V																																										
DART	2015	ESM (Electronic Shifter Module)	V			V																																										
DART	2015	HVAC (Heat Vent A/C)	V			V																																										
DART	2015	ICS (Integrated Center Stack)	V			V																																										
DART	2015	IPC (Instrument Panel Cluster)	V			V																																										
DART	2015	LBSS (Left Blind Spot Sensor)	V			V																																										
DART	2015	OCM (Occupant Classification Module)	V			V																																										
DART	2015	ORC (Occupant Restraint Control)	V			V																																										
DART	2015	RADIO (Radio)	V			V																																										
DART	2015	RBSS (Right Blind Spot Sensor)	V			V																																										
DART	2015	RFH (Radio Frequency Hub)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
DART	2015	SCM (Steering Column Module)	V			V																																										
DART	2015	TCM (Transmission Control Module)	V			V																																										
DART	2015	WCM(Wireless Control Modules)	V			V																																										
DART	2014	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DART	2014	ABS (Anti Lock Brake System)	V			V																																										
DART	2014	AMP (Audio)	V			V																																										
DART	2014	BCM (Body Control Module)	V			V																																										
DART	2014	FDCM/AWD (Final Drive Control / All Wheel Drive)	V			V																																										
DART	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
DART	2014	CGW (Central Gateway)	V			V																																										
DART	2014	EDM (Electronic Damper Module)	V			V																																										
DART	2014	EPS (Electric Power Steering)	V			V																																										
DART	2014	ESM (Electronic Shifter Module)	V			V																																										
DART	2014	HVAC (Heat Vent A/C)	V			V																																										
DART	2014	ICS (Integrated Center Stack)	V			V																																										
DART	2014	IPC (Instrument Panel Cluster)	V			V																																										
DART	2014	LBSS (Left Blind Spot Sensor)	V			V																																										
DART	2014	OCM (Occupant Classification Module)	V			V																																										
DART	2014	ORC (Occupant Restraint Control)	V			V																																										
DART	2014	RADIO (Radio)	V			V																																										
DART	2014	RBSS (Right Blind Spot Sensor)	V			V																																										
DART	2014	RFH (Radio Frequency Hub)	V			V																																										
DART	2014	SCM (Steering Column Module)	V			V																																										
DART	2014	TCM (Transmission Control Module)	V			V																																										
DART	2014	WCM(Wireless Control Modules)	V			V																																										
DART	2013	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DART	2013	ABS (Anti Lock Brake System)	V			V																																										
DART	2013	AMP (Audio)	V			V																																										
DART	2013	BCM (Body Control Module)	V			V																																										
DART	2013	FDCM/AWD (Final Drive Control / All Wheel Drive)	V			V																																										
DART	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
DART	2013	CGW (Central Gateway)	V			V																																										
DART	2013	EDM (Electronic Damper Module)	V			V																																										
DART	2013	EPS (Electric Power Steering)	V			V																																										
DART	2013	ESM (Electronic Shifter Module)	V			V																																										
DART	2013	HVAC (Heat Vent A/C)	V			V																																										
DART	2013	ICS (Integrated Center Stack)	V			V																																										
DART	2013	IPC (Instrument Panel Cluster)	V			V																																										
DART	2013	LBSS (Left Blind Spot Sensor)	V			V																																										
DART	2013	OCM (Occupant Classification Module)	V			V																																										
DART	2013	ORC (Occupant Restraint Control)	V			V																																										
DART	2013	RADIO (Radio)	V			V																																										
DART	2013	RBSS (Right Blind Spot Sensor)	V			V																																										
DART	2013	RFH (Radio Frequency Hub)	V			V																																										
DART	2013	SCM (Steering Column Module)	V			V																																										
DART	2013	TCM (Transmission Control Module)	V			V																																										
DART	2013	WCM(Wireless Control Modules)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
DART	2012	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
DART	2012	ABS (Anti Lock Brake System)	V			V																																										
DART	2012	AMP (Audio)	V			V																																										
DART	2012	BCM (Body Control Module)	V			V																																										
DART	2012	FDCM/AWD (Final Drive Control / All Wheel Drive)	V			V																																										
DART	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
DART	2012	CGW (Central Gateway)	V			V																																										
DART	2012	EDM (Electronic Damper Module)	V			V																																										
DART	2012	EPS (Electric Power Steering)	V			V																																										
DART	2012	ESM (Electronic Shifter Module)	V			V																																										
DART	2012	HVAC (Heat Vent A/C)	V			V																																										
DART	2012	ICS (Integrated Center Stack)	V			V																																										
DART	2012	IPC (Instrument Panel Cluster)	V			V																																										
DART	2012	LBSS (Left Blind Spot Sensor)	V			V																																										
DART	2012	OCM (Occupant Classification Module)	V			V																																										
DART	2012	ORC (Occupant Restraint Control)	V			V																																										
DART	2012	RADIO (Radio)	V			V																																										
DART	2012	RBSS (Right Blind Spot Sensor)	V			V																																										
DART	2012	RFH (Radio Frequency Hub)	V			V																																										
DART	2012	SCM (Steering Column Module)	V			V																																										
DART	2012	TCM (Transmission Control Module)	V			V																																										
DART	2012	WCM(Wireless Control Modules)	V			V																																										
VIPER	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
VIPER	2016	ABS (Anti Lock Brake System)	V			V																																										
VIPER	2016	ADCM (Adaptive Damper Control Module)	V			V																																										
VIPER	2016	AMP (Audio)	V			V																																										
VIPER	2016	BCM (Body Control Module)	V			V																																										
VIPER	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
VIPER	2016	CGW (Central Gateway)	V			V																																										
VIPER	2016	DDM (Drivers Door Module)	V			V																																										
VIPER	2016	HVAC (Heat Vent A/C)	V			V																																										
VIPER	2016	ICS (Integrated Center Stack)	V			V																																										
VIPER	2016	IPC (Instrument Panel Cluster)	V			V																																										
VIPER	2016	OCM (Occupant Classification Module)	V			V																																										
VIPER	2016	ORC (Occupant Restraint Control)	V			V																																										
VIPER	2016	PDM (Passenger Door Module)	V			V																																										
VIPER	2016	RADIO (Radio)	V			V																																										
VIPER	2016	RFH (Radio Frequency Hub)	V			V																																										
VIPER	2016	SCM (Steering Column Module)	V			V																																										
VIPER	2016	TPM (Tire Pressure Monitor)	V			V																																										
VIPER	2016	WCM(Wireless Control Modules)	V			V																																										
VIPER	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
VIPER	2015	ABS (Anti Lock Brake System)	V			V																																										
VIPER	2015	ADCM (Adaptive Damper Control Module)	V			V																																										
VIPER	2015	AMP (Audio)	V			V																																										
VIPER	2015	BCM (Body Control Module)	V			V																																										
VIPER	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
VIPER	2015	CGW (Central Gateway)	V			V																																										
VIPER	2015	DDM (Drivers Door Module)	V			V																																										
VIPER	2015	HVAC (Heat Vent A/C)	V			V																																										
VIPER	2015	ICS (Integrated Center Stack)	V			V																																										
VIPER	2015	IPC (Instrument Panel Cluster)	V			V																																										
VIPER	2015	OCM (Occupant Classification Module)	V			V																																										
VIPER	2015	ORC (Occupant Restraint Control)	V			V																																										
VIPER	2015	PDM (Passenger Door Module)	V			V																																										
VIPER	2015	RADIO (Radio)	V			V																																										
VIPER	2015	RFH (Radio Frequency Hub)	V			V																																										
VIPER	2015	SCM (Steering Column Module)	V			V																																										
VIPER	2015	TPM (Tire Pressure Monitor)	V			V																																										
VIPER	2015	WCM(Wireless Control Modules)	V			V																																										
VIPER	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
VIPER	2014	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
VIPER	2014	AMP (Audio)	V	V		V																																										
VIPER	2014	DDM (Drivers Door Module)	V	V	V	V																																										
VIPER	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
VIPER	2014	OCM (Occupant Classification Module)	V			V																																										
VIPER	2014	ORC (Occupant Restraint Control)	V	V		V																																										
VIPER	2014	PDM (Passenger Door Module)	V	V	V	V																																										
VIPER	2014	RADIO (Radio)	V	V		V																																										
VIPER	2014	TPM (Tire Pressure Monitor)	V			V																																										
VIPER	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
VIPER	2013	ABS (Anti Lock Brake System)	V	V	V	V																																						V	V	V	V
VIPER	2013	AMP (Audio)	V	V		V																																										
VIPER	2013	DDM (Drivers Door Module)	V	V	V	V																																										
VIPER	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
VIPER	2013	OCM (Occupant Classification Module)	V			V																																										
VIPER	2013	ORC (Occupant Restraint Control)	V	V		V																																										
VIPER	2013	PDM (Passenger Door Module)	V	V	V	V																																										
VIPER	2013	RADIO (Radio)	V	V		V																																										
VIPER	2013	TPM (Tire Pressure Monitor)	V			V																																										
VIPER	2012	ORC (Occupant Restraint Control)	V			V																																										
VIPER	2012	PDM (Passenger Door Module)	V	V	V	V																																										
VIPER	2012	RADIO (Radio)	V	V		V																																										
VIPER	2012	TPM (Tire Pressure Monitor)	V			V																																										
VIPER	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
VIPER	2010	OCM (Occupant Classification Module)	V			V																																										
VIPER	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
VIPER	2009	OCM (Occupant Classification Module)	V			V																																										
VIPER	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
VIPER	2008	OCM (Occupant Classification Module)	V			V																																										

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
General(CAN Bus)	ALL	PCM (Powertrain Control Module)																																														
General(CAN Bus)	ALL	ABS (Anti Lock Brake System)	V																																													
General(CAN Bus)	ALL	ACC (Adaptive Cruise Control)																																														
General(CAN Bus)	ALL	ADCM (Adaptive Damper Control Module)																																														
General(CAN Bus)	ALL	AFLS (Adaptive Front Light System)																																														
General(CAN Bus)	ALL	AHBM (Automatic High Beam)																																														
General(CAN Bus)	ALL	AMP (Audio)																						V	V																							
General(CAN Bus)	ALL	BCM (Body Control Module)																																														
General(CAN Bus)	ALL	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
General(CAN Bus)	ALL	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
General(CAN Bus)	ALL	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
General(CAN Bus)	ALL	DDM (Drivers Door Module)																					V																										
General(CAN Bus)	ALL	DTCM (Drive Train Control Module)																																														
General(CAN Bus)	ALL	EDM (Electronic Damper Module)																																														
General(CAN Bus)	ALL	EOM (Electric Overhead Module)																																											V			
General(CAN Bus)	ALL	EPB (Electrical Parking Brake)																																														V
General(CAN Bus)	ALL	EPS (Electric Power Steering)																																														
General(CAN Bus)	ALL	ESM (Electronic Shifter Module)																																														
General(CAN Bus)	ALL	FFCM (Front Facing Camera Module)																																													V	
General(CAN Bus)	ALL	HFM (Hands Free Module)																																								V						
General(CAN Bus)	ALL	HSM (Heated Seat Module)																																														
General(CAN Bus)	ALL	HVAC (Heat Vent A/C)																								V	V	V	V																			
General(CAN Bus)	ALL	ICS (Integrated Center Stack)																																														
General(CAN Bus)	ALL	IPC (Instrument Panel Cluster)																																														
General(CAN Bus)	ALL	ITM (Intrusion)																																														
General(CAN Bus)	ALL	LBSS (Left Blind Spot Sensor)																																														
General(CAN Bus)	ALL	LRSM (Light Rain Sensor Module)																																														
General(CAN Bus)	ALL	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
General(CAN Bus)	ALL	OCM (Occupant Classification Module)																																														
General(CAN Bus)	ALL	ORC (Occupant Restraint Control)		V																																												
General(CAN Bus)	ALL	PDM (Passenger Door Module)																																														
General(CAN Bus)	ALL	PLM (Power Liftgate Module)																																														
General(CAN Bus)	ALL	PTS (Park Assist Module)																																														
General(CAN Bus)	ALL	RADIO (Radio)																																				V	V	V	V							
General(CAN Bus)	ALL	RBSS (Right Blind Spot Sensor)																																														
General(CAN Bus)	ALL	RFH (Radio Frequency Hub)																																														
General(CAN Bus)	ALL	SAS (Steering Angle Sensor)																																														
General(CAN Bus)	ALL	SCM (Steering Column Module)																																														
General(CAN Bus)	ALL	SDAR (Satellite Radio)																																														
General(CAN Bus)	ALL	SUNR (Sunroof Module)																																														
General(CAN Bus)	ALL	TCM (Transmission Control Module)																																														
General(CAN Bus)	ALL	TGW (Telematics Gateway)																																														
General(CAN Bus)	ALL	TPM (Tire Pressure Monitor)																																														
General(CAN Bus)	ALL	VES3 (Vidio Entertainment System 3)																																														
General(CAN Bus)	ALL	WCM(Wireless Control Modules)														V																											V	V				
DURANGO	2016	PCM (Powertrain Control Module)																																														
DURANGO	2016	ABS (Anti Lock Brake System)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
DURANGO	2016	ACC (Adaptive Cruise Control)																																														
DURANGO	2016	AMP (Audio)																																														
DURANGO	2016	BCM (Body Control Module)																																														
DURANGO	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
DURANGO	2016	CGW (Central Gateway)																																														
DURANGO	2016	DDM (Drivers Door Module)																																														
DURANGO	2016	DTCM (Drive Train Control Module)																																														
DURANGO	2016	EDM (Electronic Damper Module)																																														
DURANGO	2016	EPS (Electric Power Steering)																																														
DURANGO	2016	ESM (Electronic Shifter Module)																																														
DURANGO	2016	FFCM (Front Facing Camera Module)																																													V	
DURANGO	2016	HSM (Heated Seat Module)																																														
DURANGO	2016	HVAC (Heat Vent A/C)																																														
DURANGO	2016	ICS (Integrated Center Stack)																																														
DURANGO	2016	IPC (Instrument Panel Cluster)																																														
DURANGO	2016	ITM (Intrusion)																																														
DURANGO	2016	LBSS (Left Blind Spot Sensor)																																														
DURANGO	2016	MSMD (Memory Seet Module)																																														
DURANGO	2016	ORC (Occupant Restraint Control)																																														
DURANGO	2016	PDM (Passenger Door Module)																																														
DURANGO	2016	PLM (Power Liftgate Module)																																														
DURANGO	2016	PTS (Park Assist Module)																																														
DURANGO	2016	RADIO (Radio)																																														
DURANGO	2016	RBSS (Right Blind Spot Sensor)																																														
DURANGO	2016	RFH (Radio Frequency Hub)																																														
DURANGO	2016	SCM (Steering Column Module)																																														
DURANGO	2016	TCM (Transmission Control Module)																																														
DURANGO	2016	TPM (Tire Pressure Monitor)																																														
DURANGO	2016	VES3 (Vidio Entertainment System 3)																																														
DURANGO	2016	WCM(Wireless Control Modules)																																														
DURANGO	2015	PCM (Powertrain Control Module)																																														
DURANGO	2015	ABS (Anti Lock Brake System)																																														
DURANGO	2015	ACC (Adaptive Cruise Control)																																														
DURANGO	2015	AMP (Audio)																																														
DURANGO	2015	BCM (Body Control Module)																																														
DURANGO	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
DURANGO	2015	CGW (Central Gateway)																																														
DURANGO	2015	DDM (Drivers Door Module)																																														
DURANGO	2015	DTCM (Drive Train Control Module)																																														
DURANGO	2015	EDM (Electronic Damper Module)																																														
DURANGO	2015	EPS (Electric Power Steering)																																														
DURANGO	2015	ESM (Electronic Shifter Module)																																														
DURANGO	2015	FFCM (Front Facing Camera Module)																																													V	
DURANGO	2015	HSM (Heated Seat Module)																																														
DURANGO	2015	HVAC (Heat Vent A/C)																																														
DURANGO	2015	ICS (Integrated Center Stack)																																														
DURANGO	2015	IPC (Instrument Panel Cluster)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
DURANGO	2015	ITM (Intrusion)																																														
DURANGO	2015	LBSS (Left Blind Spot Sensor)																																														
DURANGO	2015	MSMD (Memory Seet Module)																																														
DURANGO	2015	ORC (Occupant Restraint Control)																																														
DURANGO	2015	PDM (Passenger Door Module)																																														
DURANGO	2015	PLM (Power Liftgate Module)																																														
DURANGO	2015	PTS (Park Assist Module)																																														
DURANGO	2015	RADIO (Radio)																																														
DURANGO	2015	RBSS (Right Blind Spot Sensor)																																														
DURANGO	2015	RFH (Radio Frequency Hub)																																														
DURANGO	2015	SCM (Steering Column Module)																																														
DURANGO	2015	TCM (Transmission Control Module)																																														
DURANGO	2015	TPM (Tire Pressure Monitor)																																														
DURANGO	2015	VES3 (Vidio Entertainment System 3)																																														
DURANGO	2015	WCM(Wireless Control Modules)																																														
DURANGO	2014	PCM (Powertrain Control Module)																																														
DURANGO	2014	ABS (Anti Lock Brake System)	V																																													
DURANGO	2014	ACC (Adaptive Cruise Control)																																														
DURANGO	2014	AMP (Audio)																						V	V																							
DURANGO	2014	DDM (Drivers Door Module)																					V																										
DURANGO	2014	DTCM (Drive Train Control Module)																																														
DURANGO	2014	ESM (Electronic Shifter Module)																																														
DURANGO	2014	FFCM (Front Facing Camera Module)																																													V	
DURANGO	2014	HSM (Heated Seat Module)																																														
DURANGO	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
DURANGO	2014	ITM (Intrusion)																																														
DURANGO	2014	ORC (Occupant Restraint Control)		V																																												
DURANGO	2014	PDM (Passenger Door Module)																																														
DURANGO	2014	PLM (Power Liftgate Module)																																														
DURANGO	2014	PTS (Park Assist Module)																																														
DURANGO	2014	RADIO (Radio)																																				V	V	V	V							
DURANGO	2014	TCM (Transmission Control Module)																																														
DURANGO	2014	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
DURANGO	2014	TPM (Tire Pressure Monitor)																																														
DURANGO	2014	VES3 (Vidio Entertainment System 3)																																														
DURANGO	2013	PCM (Powertrain Control Module)																																														
DURANGO	2013	ABS (Anti Lock Brake System)	V																																													
DURANGO	2013	ACC (Adaptive Cruise Control)																																														
DURANGO	2013	AHBM (Automatic High Beam)																																														
DURANGO	2013	AMP (Audio)																						V	V																							
DURANGO	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DURANGO	2013	DTCM (Drive Train Control Module)																																														
DURANGO	2013	ESM (Electronic Shifter Module)																																														
DURANGO	2013	HFM (Hands Free Module)																																								V						
DURANGO	2013	HSM (Heated Seat Module)																																														
DURANGO	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
DURANGO	2013	ITM (Intrusion)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
DURANGO	2013	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
DURANGO	2013	ORC (Occupant Restraint Control)		V																																												
DURANGO	2013	PLM (Power Liftgate Module)																																														
DURANGO	2013	PTS (Park Assist Module)																																														
DURANGO	2013	RADIO (Radio)																																				V	V	V	V							
DURANGO	2013	SAS (Steering Angle Sensor)																																														
DURANGO	2013	TCM (Transmission Control Module)																																														
DURANGO	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
DURANGO	2013	TPM (Tire Pressure Monitor)																																														
DURANGO	2013	VES3 (Vidio Entertainment System 3)																																														
DURANGO	2013	WCM(Wireless Control Modules)														V																												V	V			
DURANGO	2012	PCM (Powertrain Control Module)																																														
DURANGO	2012	ABS (Anti Lock Brake System)	V																																													
DURANGO	2012	ACC (Adaptive Cruise Control)																																														
DURANGO	2012	AHBM (Automatic High Beam)																																														
DURANGO	2012	AMP (Audio)																						V	V																							
DURANGO	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DURANGO	2012	DTCM (Drive Train Control Module)																																														
DURANGO	2012	ESM (Electronic Shifter Module)																																														
DURANGO	2012	HFM (Hands Free Module)																																								V						
DURANGO	2012	HSM (Heated Seat Module)																																														
DURANGO	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
DURANGO	2012	ITM (Intrusion)																																														
DURANGO	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
DURANGO	2012	ORC (Occupant Restraint Control)		V																																												
DURANGO	2012	PLM (Power Liftgate Module)																																														
DURANGO	2012	PTS (Park Assist Module)																																														
DURANGO	2012	RADIO (Radio)																																				V	V	V	V							
DURANGO	2012	SAS (Steering Angle Sensor)																																														
DURANGO	2012	TCM (Transmission Control Module)																																														
DURANGO	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
DURANGO	2012	TPM (Tire Pressure Monitor)																																														
DURANGO	2012	VES3 (Vidio Entertainment System 3)																																														
DURANGO	2012	WCM(Wireless Control Modules)														V																												V	V			
DURANGO	2011	PCM (Powertrain Control Module)																																														
DURANGO	2011	ABS (Anti Lock Brake System)	V																																													
DURANGO	2011	ACC (Adaptive Cruise Control)																																														
DURANGO	2011	AHBM (Automatic High Beam)																																														
DURANGO	2011	AMP (Audio)																						V	V																							
DURANGO	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DURANGO	2011	DTCM (Drive Train Control Module)																																														
DURANGO	2011	ESM (Electronic Shifter Module)																																														
DURANGO	2011	HFM (Hands Free Module)																																								V						
DURANGO	2011	HSM (Heated Seat Module)																																														
DURANGO	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
DURANGO	2011	ITM (Intrusion)																																														
DURANGO	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
DURANGO	2011	ORC (Occupant Restraint Control)		V																																												
DURANGO	2011	PLM (Power Liftgate Module)																																														
DURANGO	2011	PTS (Park Assist Module)																																														
DURANGO	2011	RADIO (Radio)																																				V	V	V	V							
DURANGO	2011	SAS (Steering Angle Sensor)																																														
DURANGO	2011	TCM (Transmission Control Module)																																														
DURANGO	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
DURANGO	2011	TPM (Tire Pressure Monitor)																																														
DURANGO	2011	VES3 (Vidio Entertainment System 3)																																														
DURANGO	2011	WCM(Wireless Control Modules)														V																											V	V				
DURANGO	2009	PCM (Powertrain Control Module)																																														
DURANGO	2009	ABS (Anti Lock Brake System)	V																																													
DURANGO	2009	AMP (Audio)																						V	V																							
DURANGO	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DURANGO	2009	DDM (Drivers Door Module)																					V																									
DURANGO	2009	EOM (Electric Overhead Module)																																											V			
DURANGO	2009	HFM (Hands Free Module)																																								V						
DURANGO	2009	HSM (Heated Seat Module)																																														
DURANGO	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
DURANGO	2009	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
DURANGO	2009	ORC (Occupant Restraint Control)		V																																												
DURANGO	2009	PDM (Passenger Door Module)																																														
DURANGO	2009	PLM (Power Liftgate Module)																																														
DURANGO	2009	PTS (Park Assist Module)																																														
DURANGO	2009	RADIO (Radio)																																				V	V	V	V							
DURANGO	2009	SAS (Steering Angle Sensor)																																														
DURANGO	2009	TCM (Transmission Control Module)																																														
DURANGO	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
DURANGO	2009	VES3 (Vidio Entertainment System 3)																																														
DURANGO	2009	WCM(Wireless Control Modules)														V																											V	V				
DURANGO	2008	PCM (Powertrain Control Module)																																														
DURANGO	2008	ABS (Anti Lock Brake System)	V																																													
DURANGO	2008	AMP (Audio)																						V	V																							
DURANGO	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DURANGO	2008	DDM (Drivers Door Module)																					V																									
DURANGO	2008	EOM (Electric Overhead Module)																																											V			
DURANGO	2008	HFM (Hands Free Module)																																								V						
DURANGO	2008	HSM (Heated Seat Module)																																														
DURANGO	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
DURANGO	2008	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
DURANGO	2008	ORC (Occupant Restraint Control)		V																																												
DURANGO	2008	PDM (Passenger Door Module)																																														
DURANGO	2008	PLM (Power Liftgate Module)																																														
DURANGO	2008	PTS (Park Assist Module)																																														
DURANGO	2008	RADIO (Radio)																																				V	V	V	V							
DURANGO	2008	SAS (Steering Angle Sensor)																																														
DURANGO	2008	VES3 (Vidio Entertainment System 3)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
DURANGO	2008	WCM(Wireless Control Modules)														V																												V	V			
DURANGO	2007	PCM (Powertrain Control Module)																																														
DURANGO	2007	ABS (Anti Lock Brake System)	V																																													
DURANGO	2007	AMP (Audio)																						V	V																							
DURANGO	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DURANGO	2007	DDM (Drivers Door Module)																					V																									
DURANGO	2007	EOM (Electric Overhead Module)																																											V			
DURANGO	2007	HFM (Hands Free Module)																																								V						
DURANGO	2007	HSM (Heated Seat Module)																																														
DURANGO	2007	HVAC (Heat Vent A/C)																								V	V	V	V																			
DURANGO	2007	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
DURANGO	2007	ORC (Occupant Restraint Control)		V																																												
DURANGO	2007	PDM (Passenger Door Module)																																														
DURANGO	2007	PLM (Power Liftgate Module)																																														
DURANGO	2007	PTS (Park Assist Module)																																														
DURANGO	2007	RADIO (Radio)																																					V	V	V	V						
DURANGO	2007	SAS (Steering Angle Sensor)																																														
DURANGO	2007	SDAR (Satellite Radio)																																														
DURANGO	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
DURANGO	2007	WCM(Wireless Control Modules)														V																												V	V			
DURANGO	2006	PCM (Powertrain Control Module)																																														
DURANGO	2006	ABS (Anti Lock Brake System)	V																																													
DURANGO	2006	AMP (Audio)																						V	V																							
DURANGO	2006	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DURANGO	2006	DDM (Drivers Door Module)																					V																									
DURANGO	2006	EOM (Electric Overhead Module)																																											V			
DURANGO	2006	HFM (Hands Free Module)																																								V						
DURANGO	2006	HSM (Heated Seat Module)																																														
DURANGO	2006	HVAC (Heat Vent A/C)																								V	V	V	V																			
DURANGO	2006	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
DURANGO	2006	OCM (Occupant Classification Module)																																														
DURANGO	2006	ORC (Occupant Restraint Control)		V																																												
DURANGO	2006	PDM (Passenger Door Module)																																														
DURANGO	2006	PLM (Power Liftgate Module)																																														
DURANGO	2006	RADIO (Radio)																																					V	V	V	V						
DURANGO	2006	SAS (Steering Angle Sensor)																																														
DURANGO	2006	SDAR (Satellite Radio)																																														
DURANGO	2006	TCM (Transmission Control Module)																																														
DURANGO	2006	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
DURANGO	2006	WCM(Wireless Control Modules)														V																												V	V			
DURANGO	2005	PCM (Powertrain Control Module)																																														
DURANGO	2005	ABS (Anti Lock Brake System)	V																																													
DURANGO	2005	AMP (Audio)																						V	V																							
DURANGO	2005	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DURANGO	2005	DDM (Drivers Door Module)																					V																									
DURANGO	2005	EOM (Electric Overhead Module)																																											V			
DURANGO	2005	HFM (Hands Free Module)																																								V						

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
DURANGO	2005	HSM (Heated Seat Module)																																														
DURANGO	2005	HVAC (Heat Vent A/C)																								V	V	V	V																			
DURANGO	2005	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
DURANGO	2005	OCM (Occupant Classification Module)																																														
DURANGO	2005	ORC (Occupant Restraint Control)		V																																												
DURANGO	2005	PDM (Passenger Door Module)																																														
DURANGO	2005	RADIO (Radio)																																				V	V	V	V							
DURANGO	2005	SDAR (Satellite Radio)																																														
DURANGO	2005	TCM (Transmission Control Module)																																														
DURANGO	2005	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
DURANGO	2005	WCM(Wireless Control Modules)														V																											V	V				
DURANGO	2004	PCM (Powertrain Control Module)																																														
DURANGO	2004	ABS (Anti Lock Brake System)	V																																													
DURANGO	2004	AMP (Audio)																						V	V																							
DURANGO	2004	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DURANGO	2004	DDM (Drivers Door Module)																					V																									
DURANGO	2004	EOM (Electric Overhead Module)																																											V			
DURANGO	2004	HFM (Hands Free Module)																																								V						
DURANGO	2004	HSM (Heated Seat Module)																																														
DURANGO	2004	HVAC (Heat Vent A/C)																								V	V	V	V																			
DURANGO	2004	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
DURANGO	2004	OCM (Occupant Classification Module)																																														
DURANGO	2004	ORC (Occupant Restraint Control)		V																																												
DURANGO	2004	PDM (Passenger Door Module)																																														
DURANGO	2004	RADIO (Radio)																																				V	V	V	V							
DURANGO	2004	SDAR (Satellite Radio)																																														
DURANGO	2004	TCM (Transmission Control Module)																																														
DURANGO	2004	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
DURANGO	2004	WCM(Wireless Control Modules)														V																											V	V				
MAGNUM	2016	PCM (Powertrain Control Module)																																														
MAGNUM	2016	ABS (Anti Lock Brake System)																																														
MAGNUM	2016	ACC (Adaptive Cruise Control)																																														
MAGNUM	2016	ADCM (Adaptive Damper Control Module)																																														
MAGNUM	2016	AFLS (Adaptive Front Light System)																																														
MAGNUM	2016	AMP (Audio)																																														
MAGNUM	2016	BCM (Body Control Module)																																														
MAGNUM	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
MAGNUM	2016	CGW (Central Gateway)																																														
MAGNUM	2016	DDM (Drivers Door Module)																																														
MAGNUM	2016	DTCM (Drive Train Control Module)																																														
MAGNUM	2016	EPS (Electric Power Steering)																																														
MAGNUM	2016	ESM (Electronic Shifter Module)																																														
MAGNUM	2016	FFCM (Front Facing Camera Module)																																												V		
MAGNUM	2016	HSM (Heated Seat Module)																																														
MAGNUM	2016	HVAC (Heat Vent A/C)																																														
MAGNUM	2016	ICS (Integrated Center Stack)																																														
MAGNUM	2016	IPC (Instrument Panel Cluster)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
MAGNUM	2016	ITM (Intrusion)																																														
MAGNUM	2016	LBSS (Left Blind Spot Sensor)																																														
MAGNUM	2016	ORC (Occupant Restraint Control)																																														
MAGNUM	2016	PDM (Passenger Door Module)																																														
MAGNUM	2016	PTS (Park Assist Module)																																														
MAGNUM	2016	RADIO (Radio)																																														
MAGNUM	2016	RBSS (Right Blind Spot Sensor)																																														
MAGNUM	2016	RFH (Radio Frequency Hub)																																														
MAGNUM	2016	SCM (Steering Column Module)																																														
MAGNUM	2016	TCM (Transmission Control Module)																																														
MAGNUM	2016	WCM(Wireless Control Modules)																																														
MAGNUM	2015	PCM (Powertrain Control Module)																																														
MAGNUM	2015	ABS (Anti Lock Brake System)																																														
MAGNUM	2015	ACC (Adaptive Cruise Control)																																														
MAGNUM	2015	ADCM (Adaptive Damper Control Module)																																														
MAGNUM	2015	AFLS (Adaptive Front Light System)																																														
MAGNUM	2015	AMP (Audio)																																														
MAGNUM	2015	BCM (Body Control Module)																																														
MAGNUM	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
MAGNUM	2015	CGW (Central Gateway)																																														
MAGNUM	2015	DDM (Drivers Door Module)																																														
MAGNUM	2015	DTCM (Drive Train Control Module)																																														
MAGNUM	2015	EPS (Electric Power Steering)																																														
MAGNUM	2015	ESM (Electronic Shifter Module)																																														
MAGNUM	2015	FFCM (Front Facing Camera Module)																																												V		
MAGNUM	2015	HSM (Heated Seat Module)																																														
MAGNUM	2015	HVAC (Heat Vent A/C)																																														
MAGNUM	2015	ICS (Integrated Center Stack)																																														
MAGNUM	2015	IPC (Instrument Panel Cluster)																																														
MAGNUM	2015	ITM (Intrusion)																																														
MAGNUM	2015	LBSS (Left Blind Spot Sensor)																																														
MAGNUM	2015	ORC (Occupant Restraint Control)																																														
MAGNUM	2015	PDM (Passenger Door Module)																																														
MAGNUM	2015	PTS (Park Assist Module)																																														
MAGNUM	2015	RADIO (Radio)																																														
MAGNUM	2015	RBSS (Right Blind Spot Sensor)																																														
MAGNUM	2015	RFH (Radio Frequency Hub)																																														
MAGNUM	2015	SCM (Steering Column Module)																																														
MAGNUM	2015	TCM (Transmission Control Module)																																														
MAGNUM	2015	WCM(Wireless Control Modules)																																														
MAGNUM	2014	PCM (Powertrain Control Module)																																														
MAGNUM	2014	ABS (Anti Lock Brake System)	V																																													
MAGNUM	2014	ACC (Adaptive Cruise Control)																																														
MAGNUM	2014	AMP (Audio)																						V	V																							
MAGNUM	2014	DDM (Drivers Door Module)																					V																									
MAGNUM	2014	DTCM (Drive Train Control Module)																																														
MAGNUM	2014	ESM (Electronic Shifter Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
MAGNUM	2014	HFM (Hands Free Module)																																								V					
MAGNUM	2014	HSM (Heated Seat Module)																																													
MAGNUM	2014	HVAC (Heat Vent A/C)																								V	V	V	V																		
MAGNUM	2014	ITM (Intrusion)																																													
MAGNUM	2014	ORC (Occupant Restraint Control)		V																																											
MAGNUM	2014	PDM (Passenger Door Module)																																													
MAGNUM	2014	PTS (Park Assist Module)																																													
MAGNUM	2014	TCM (Transmission Control Module)																																													
MAGNUM	2014	TPM (Tire Pressure Monitor)																																													
MAGNUM	2013	PCM (Powertrain Control Module)																																													
MAGNUM	2013	ABS (Anti Lock Brake System)	V																																												
MAGNUM	2013	ACC (Adaptive Cruise Control)																																													
MAGNUM	2013	AMP (Audio)																						V	V																						
MAGNUM	2013	DDM (Drivers Door Module)																					V																								
MAGNUM	2013	DTCM (Drive Train Control Module)																																													
MAGNUM	2013	ESM (Electronic Shifter Module)																																													
MAGNUM	2013	HFM (Hands Free Module)																																								V					
MAGNUM	2013	HSM (Heated Seat Module)																																													
MAGNUM	2013	HVAC (Heat Vent A/C)																								V	V	V	V																		
MAGNUM	2013	ITM (Intrusion)																																													
MAGNUM	2013	ORC (Occupant Restraint Control)		V																																											
MAGNUM	2013	PDM (Passenger Door Module)																																													
MAGNUM	2013	PTS (Park Assist Module)																																													
MAGNUM	2013	TCM (Transmission Control Module)																																													
MAGNUM	2013	TPM (Tire Pressure Monitor)																																													
MAGNUM	2012	PCM (Powertrain Control Module)																																													
MAGNUM	2012	ABS (Anti Lock Brake System)	V																																												
MAGNUM	2012	ACC (Adaptive Cruise Control)																																													
MAGNUM	2012	AMP (Audio)																						V	V																						
MAGNUM	2012	DDM (Drivers Door Module)																					V																								
MAGNUM	2012	DTCM (Drive Train Control Module)																																													
MAGNUM	2012	ESM (Electronic Shifter Module)																																													
MAGNUM	2012	HFM (Hands Free Module)																																								V					
MAGNUM	2012	HSM (Heated Seat Module)																																													
MAGNUM	2012	HVAC (Heat Vent A/C)																								V	V	V	V																		
MAGNUM	2012	ITM (Intrusion)																																													
MAGNUM	2012	ORC (Occupant Restraint Control)		V																																											
MAGNUM	2012	PDM (Passenger Door Module)																																													
MAGNUM	2012	PTS (Park Assist Module)																																													
MAGNUM	2012	TCM (Transmission Control Module)																																													
MAGNUM	2012	TPM (Tire Pressure Monitor)																																													
MAGNUM	2011	PCM (Powertrain Control Module)																																													
MAGNUM	2011	ABS (Anti Lock Brake System)	V																																												
MAGNUM	2011	ACC (Adaptive Cruise Control)																																													
MAGNUM	2011	AMP (Audio)																						V	V																						
MAGNUM	2011	DDM (Drivers Door Module)																					V																								
MAGNUM	2011	DTCM (Drive Train Control Module)																																													

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
MAGNUM	2011	ESM (Electronic Shifter Module)																																														
MAGNUM	2011	HFM (Hands Free Module)																																								V						
MAGNUM	2011	HSM (Heated Seat Module)																																														
MAGNUM	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
MAGNUM	2011	ORC (Occupant Restraint Control)		V																																												
MAGNUM	2011	PDM (Passenger Door Module)																																														
MAGNUM	2011	PTS (Park Assist Module)																																														
MAGNUM	2011	TCM (Transmission Control Module)																																														
MAGNUM	2011	TPM (Tire Pressure Monitor)																																														
MAGNUM	2010	PCM (Powertrain Control Module)																																														
MAGNUM	2010	ABS (Anti Lock Brake System)	V																																													
MAGNUM	2010	ACC (Adaptive Cruise Control)																																														
MAGNUM	2010	AHBM (Automatic High Beam)																																														
MAGNUM	2010	AMP (Audio)																						V	V																							
MAGNUM	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
MAGNUM	2010	DDM (Drivers Door Module)																					V																									
MAGNUM	2010	DTCM (Drive Train Control Module)																																														
MAGNUM	2010	EOM (Electric Overhead Module)																																											V			
MAGNUM	2010	ESM (Electronic Shifter Module)																																														
MAGNUM	2010	HFM (Hands Free Module)																																								V						
MAGNUM	2010	HSM (Heated Seat Module)																																														
MAGNUM	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
MAGNUM	2010	ITM (Intrusion)																																														
MAGNUM	2010	LRSM (Light Rain Sensor Module)																																														
MAGNUM	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
MAGNUM	2010	ORC (Occupant Restraint Control)		V																																												
MAGNUM	2010	PDM (Passenger Door Module)																																														
MAGNUM	2010	PTS (Park Assist Module)																																														
MAGNUM	2010	RADIO (Radio)																																				V	V	V	V							
MAGNUM	2010	SCM (Steering Column Module)																																														
MAGNUM	2010	SUNR (Sunroof Module)																																														
MAGNUM	2010	TCM (Transmission Control Module)																																														
MAGNUM	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
MAGNUM	2010	TPM (Tire Pressure Monitor)																																														
MAGNUM	2010	VES3 (Vidio Entertainment System 3)																																														
MAGNUM	2010	WCM(Wireless Control Modules)														V																											V	V				
MAGNUM	2009	PCM (Powertrain Control Module)																																														
MAGNUM	2009	ABS (Anti Lock Brake System)	V																																													
MAGNUM	2009	ACC (Adaptive Cruise Control)																																														
MAGNUM	2009	AHBM (Automatic High Beam)																																														
MAGNUM	2009	AMP (Audio)																						V	V																							
MAGNUM	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
MAGNUM	2009	DDM (Drivers Door Module)																					V																									
MAGNUM	2009	DTCM (Drive Train Control Module)																																														
MAGNUM	2009	EOM (Electric Overhead Module)																																											V			
MAGNUM	2009	ESM (Electronic Shifter Module)																																														
MAGNUM	2009	HFM (Hands Free Module)																																								V						

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
MAGNUM	2009	HSM (Heated Seat Module)																																														
MAGNUM	2009	HVAC (Heat Vent A/C)																								V	V	V	V																		
MAGNUM	2009	ITM (Intrusion)																																														
MAGNUM	2009	LRSM (Light Rain Sensor Module)																																														
MAGNUM	2009	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
MAGNUM	2009	ORC (Occupant Restraint Control)		V																																												
MAGNUM	2009	PDM (Passenger Door Module)																																														
MAGNUM	2009	PTS (Park Assist Module)																																														
MAGNUM	2009	RADIO (Radio)																																				V	V	V	V							
MAGNUM	2009	SCM (Steering Column Module)																																														
MAGNUM	2009	SUNR (Sunroof Module)																																														
MAGNUM	2009	TCM (Transmission Control Module)																																														
MAGNUM	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
MAGNUM	2009	TPM (Tire Pressure Monitor)																																														
MAGNUM	2009	VES3 (Vidio Entertainment System 3)																																														
MAGNUM	2009	WCM(Wireless Control Modules)														V																											V	V				
MAGNUM	2008	PCM (Powertrain Control Module)																																														
MAGNUM	2008	ABS (Anti Lock Brake System)	V																																													
MAGNUM	2008	ACC (Adaptive Cruise Control)																																														
MAGNUM	2008	AHBM (Automatic High Beam)																																														
MAGNUM	2008	AMP (Audio)																						V	V																							
MAGNUM	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
MAGNUM	2008	DDM (Drivers Door Module)																					V																									
MAGNUM	2008	EOM (Electric Overhead Module)																																											V			
MAGNUM	2008	ESM (Electronic Shifter Module)																																														
MAGNUM	2008	HFM (Hands Free Module)																																								V						
MAGNUM	2008	HSM (Heated Seat Module)																																														
MAGNUM	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
MAGNUM	2008	ITM (Intrusion)																																														
MAGNUM	2008	LRSM (Light Rain Sensor Module)																																														
MAGNUM	2008	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
MAGNUM	2008	ORC (Occupant Restraint Control)		V																																												
MAGNUM	2008	PDM (Passenger Door Module)																																														
MAGNUM	2008	PTS (Park Assist Module)																																														
MAGNUM	2008	RADIO (Radio)																																				V	V	V	V							
MAGNUM	2008	SCM (Steering Column Module)																																														
MAGNUM	2008	SUNR (Sunroof Module)																																														
MAGNUM	2008	TCM (Transmission Control Module)																																														
MAGNUM	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
MAGNUM	2008	VES3 (Vidio Entertainment System 3)																																														
MAGNUM	2008	WCM(Wireless Control Modules)														V																											V	V				
MAGNUM	2007	PCM (Powertrain Control Module)																																														
MAGNUM	2007	ABS (Anti Lock Brake System)	V																																													
MAGNUM	2007	ACC (Adaptive Cruise Control)																																														
MAGNUM	2007	AHBM (Automatic High Beam)																																														
MAGNUM	2007	AMP (Audio)																						V	V																							
MAGNUM	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
MAGNUM	2007	DDM (Drivers Door Module)																					V																									
MAGNUM	2007	EOM (Electric Overhead Module)																																											V			
MAGNUM	2007	ESM (Electronic Shifter Module)																																														
MAGNUM	2007	HFM (Hands Free Module)																																								V						
MAGNUM	2007	HSM (Heated Seat Module)																																														
MAGNUM	2007	HVAC (Heat Vent A/C)																								V	V	V	V																			
MAGNUM	2007	ITM (Intrusion)																																														
MAGNUM	2007	LRSM (Light Rain Sensor Module)																																														
MAGNUM	2007	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
MAGNUM	2007	ORC (Occupant Restraint Control)		V																																												
MAGNUM	2007	PDM (Passenger Door Module)																																														
MAGNUM	2007	PTS (Park Assist Module)																																														
MAGNUM	2007	RADIO (Radio)																																				V	V	V	V							
MAGNUM	2007	SCM (Steering Column Module)																																														
MAGNUM	2007	SDAR (Satellite Radio)																																														
MAGNUM	2007	SUNR (Sunroof Module)																																														
MAGNUM	2007	TCM (Transmission Control Module)																																														
MAGNUM	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
MAGNUM	2007	WCM(Wireless Control Modules)														V																											V	V				
MAGNUM	2006	PCM (Powertrain Control Module)																																														
MAGNUM	2006	ABS (Anti Lock Brake System)	V																																													
MAGNUM	2006	AHBM (Automatic High Beam)																																														
MAGNUM	2006	AMP (Audio)																						V	V																							
MAGNUM	2006	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
MAGNUM	2006	DDM (Drivers Door Module)																					V																									
MAGNUM	2006	EOM (Electric Overhead Module)																																											V			
MAGNUM	2006	ESM (Electronic Shifter Module)																																														
MAGNUM	2006	HFM (Hands Free Module)																																								V						
MAGNUM	2006	HSM (Heated Seat Module)																																														
MAGNUM	2006	HVAC (Heat Vent A/C)																								V	V	V	V																			
MAGNUM	2006	ITM (Intrusion)																																														
MAGNUM	2006	LRSM (Light Rain Sensor Module)																																														
MAGNUM	2006	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
MAGNUM	2006	OCM (Occupant Classification Module)																																														
MAGNUM	2006	ORC (Occupant Restraint Control)		V																																												
MAGNUM	2006	PDM (Passenger Door Module)																																														
MAGNUM	2006	PTS (Park Assist Module)																																														
MAGNUM	2006	RADIO (Radio)																																				V	V	V	V							
MAGNUM	2006	SCM (Steering Column Module)																																														
MAGNUM	2006	SDAR (Satellite Radio)																																														
MAGNUM	2006	SUNR (Sunroof Module)																																														
MAGNUM	2006	TCM (Transmission Control Module)																																														
MAGNUM	2006	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
MAGNUM	2006	WCM(Wireless Control Modules)														V																											V	V				
MAGNUM	2005	PCM (Powertrain Control Module)																																														
MAGNUM	2005	ABS (Anti Lock Brake System)	V																																													
MAGNUM	2005	AMP (Audio)																						V	V																							

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
MAGNUM	2005	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
MAGNUM	2005	DDM (Drivers Door Module)																					V																									
MAGNUM	2005	EOM (Electric Overhead Module)																																											V			
MAGNUM	2005	ESM (Electronic Shifter Module)																																														
MAGNUM	2005	HFM (Hands Free Module)																																								V						
MAGNUM	2005	HSM (Heated Seat Module)																																														
MAGNUM	2005	HVAC (Heat Vent A/C)																								V	V	V	V																			
MAGNUM	2005	LRSM (Light Rain Sensor Module)																																														
MAGNUM	2005	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
MAGNUM	2005	OCM (Occupant Classification Module)																																														
MAGNUM	2005	ORC (Occupant Restraint Control)		V																																												
MAGNUM	2005	PDM (Passenger Door Module)																																														
MAGNUM	2005	PTS (Park Assist Module)																																														
MAGNUM	2005	RADIO (Radio)																																				V	V	V	V							
MAGNUM	2005	SCM (Steering Column Module)																																														
MAGNUM	2005	SDAR (Satellite Radio)																																														
MAGNUM	2005	SUNR (Sunroof Module)																																														
MAGNUM	2005	TCM (Transmission Control Module)																																														
MAGNUM	2005	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
MAGNUM	2005	WCM(Wireless Control Modules)														V																											V	V				
CHARGER	2016	PCM (Powertrain Control Module)																																														
CHARGER	2016	ABS (Anti Lock Brake System)																																														
CHARGER	2016	ACC (Adaptive Cruise Control)																																														
CHARGER	2016	ADCM (Adaptive Damper Control Module)																																														
CHARGER	2016	AFLS (Adaptive Front Light System)																																														
CHARGER	2016	AMP (Audio)																																														
CHARGER	2016	BCM (Body Control Module)																																														
CHARGER	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
CHARGER	2016	CGW (Central Gateway)																																														
CHARGER	2016	DDM (Drivers Door Module)																																														
CHARGER	2016	DTCM (Drive Train Control Module)																																														
CHARGER	2016	EPS (Electric Power Steering)																																														
CHARGER	2016	ESM (Electronic Shifter Module)																																														
CHARGER	2016	FFCM (Front Facing Camera Module)																																												V		
CHARGER	2016	HSM (Heated Seat Module)																																														
CHARGER	2016	HVAC (Heat Vent A/C)																																														
CHARGER	2016	ICS (Integrated Center Stack)																																														
CHARGER	2016	IPC (Instrument Panel Cluster)																																														
CHARGER	2016	ITM (Intrusion)																																														
CHARGER	2016	LBSS (Left Blind Spot Sensor)																																														
CHARGER	2016	ORC (Occupant Restraint Control)																																														
CHARGER	2016	PDM (Passenger Door Module)																																														
CHARGER	2016	PTS (Park Assist Module)																																														
CHARGER	2016	RADIO (Radio)																																														
CHARGER	2016	RBSS (Right Blind Spot Sensor)																																														
CHARGER	2016	RFH (Radio Frequency Hub)																																														
CHARGER	2016	SCM (Steering Column Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CHARGER	2016	TCM (Transmission Control Module)																																														
CHARGER	2016	WCM(Wireless Control Modules)																																														
CHARGER	2015	PCM (Powertrain Control Module)																																														
CHARGER	2015	ABS (Anti Lock Brake System)																																														
CHARGER	2015	ACC (Adaptive Cruise Control)																																														
CHARGER	2015	ADCM (Adaptive Damper Control Module)																																														
CHARGER	2015	AFLS (Adaptive Front Light System)																																														
CHARGER	2015	AMP (Audio)																																														
CHARGER	2015	BCM (Body Control Module)																																														
CHARGER	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
CHARGER	2015	CGW (Central Gateway)																																														
CHARGER	2015	DDM (Drivers Door Module)																																														
CHARGER	2015	DTCM (Drive Train Control Module)																																														
CHARGER	2015	EPS (Electric Power Steering)																																														
CHARGER	2015	ESM (Electronic Shifter Module)																																														
CHARGER	2015	FFCM (Front Facing Camera Module)																																													V	
CHARGER	2015	HSM (Heated Seat Module)																																														
CHARGER	2015	HVAC (Heat Vent A/C)																																														
CHARGER	2015	ICS (Integrated Center Stack)																																														
CHARGER	2015	IPC (Instrument Panel Cluster)																																														
CHARGER	2015	ITM (Intrusion)																																														
CHARGER	2015	LBSS (Left Blind Spot Sensor)																																														
CHARGER	2015	ORC (Occupant Restraint Control)																																														
CHARGER	2015	PDM (Passenger Door Module)																																														
CHARGER	2015	PTS (Park Assist Module)																																														
CHARGER	2015	RADIO (Radio)																																														
CHARGER	2015	RBSS (Right Blind Spot Sensor)																																														
CHARGER	2015	RFH (Radio Frequency Hub)																																														
CHARGER	2015	SCM (Steering Column Module)																																														
CHARGER	2015	TCM (Transmission Control Module)																																														
CHARGER	2015	WCM(Wireless Control Modules)																																														
CHARGER	2014	PCM (Powertrain Control Module)																																														
CHARGER	2014	ABS (Anti Lock Brake System)	V																																													
CHARGER	2014	ACC (Adaptive Cruise Control)																																														
CHARGER	2014	AMP (Audio)																						V	V																							
CHARGER	2014	DDM (Drivers Door Module)																					V																									
CHARGER	2014	DTCM (Drive Train Control Module)																																														
CHARGER	2014	ESM (Electronic Shifter Module)																																														
CHARGER	2014	HFM (Hands Free Module)																																								V						
CHARGER	2014	HSM (Heated Seat Module)																																														
CHARGER	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHARGER	2014	ITM (Intrusion)																																														
CHARGER	2014	ORC (Occupant Restraint Control)		V																																												
CHARGER	2014	PDM (Passenger Door Module)																																														
CHARGER	2014	PTS (Park Assist Module)																																														
CHARGER	2014	TCM (Transmission Control Module)																																														
CHARGER	2014	TPM (Tire Pressure Monitor)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CHARGER	2013	PCM (Powertrain Control Module)																																														
CHARGER	2013	ABS (Anti Lock Brake System)	V																																													
CHARGER	2013	ACC (Adaptive Cruise Control)																																														
CHARGER	2013	AMP (Audio)																						V	V																							
CHARGER	2013	DDM (Drivers Door Module)																					V																									
CHARGER	2013	DTCM (Drive Train Control Module)																																														
CHARGER	2013	ESM (Electronic Shifter Module)																																														
CHARGER	2013	HFM (Hands Free Module)																																								V						
CHARGER	2013	HSM (Heated Seat Module)																																														
CHARGER	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHARGER	2013	ITM (Intrusion)																																														
CHARGER	2013	ORC (Occupant Restraint Control)		V																																												
CHARGER	2013	PDM (Passenger Door Module)																																														
CHARGER	2013	PTS (Park Assist Module)																																														
CHARGER	2013	TCM (Transmission Control Module)																																														
CHARGER	2013	TPM (Tire Pressure Monitor)																																														
CHARGER	2012	PCM (Powertrain Control Module)																																														
CHARGER	2012	ABS (Anti Lock Brake System)	V																																													
CHARGER	2012	ACC (Adaptive Cruise Control)																																														
CHARGER	2012	AMP (Audio)																						V	V																							
CHARGER	2012	DDM (Drivers Door Module)																					V																									
CHARGER	2012	DTCM (Drive Train Control Module)																																														
CHARGER	2012	ESM (Electronic Shifter Module)																																														
CHARGER	2012	HFM (Hands Free Module)																																								V						
CHARGER	2012	HSM (Heated Seat Module)																																														
CHARGER	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHARGER	2012	ITM (Intrusion)																																														
CHARGER	2012	ORC (Occupant Restraint Control)		V																																												
CHARGER	2012	PDM (Passenger Door Module)																																														
CHARGER	2012	PTS (Park Assist Module)																																														
CHARGER	2012	TCM (Transmission Control Module)																																														
CHARGER	2012	TPM (Tire Pressure Monitor)																																														
CHARGER	2011	PCM (Powertrain Control Module)																																														
CHARGER	2011	ABS (Anti Lock Brake System)	V																																													
CHARGER	2011	ACC (Adaptive Cruise Control)																																														
CHARGER	2011	AMP (Audio)																						V	V																							
CHARGER	2011	DDM (Drivers Door Module)																					V																									
CHARGER	2011	DTCM (Drive Train Control Module)																																														
CHARGER	2011	ESM (Electronic Shifter Module)																																														
CHARGER	2011	HFM (Hands Free Module)																																								V						
CHARGER	2011	HSM (Heated Seat Module)																																														
CHARGER	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHARGER	2011	ORC (Occupant Restraint Control)		V																																												
CHARGER	2011	PDM (Passenger Door Module)																																														
CHARGER	2011	PTS (Park Assist Module)																																														
CHARGER	2011	TCM (Transmission Control Module)																																														
CHARGER	2011	TPM (Tire Pressure Monitor)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CHARGER	2010	PCM (Powertrain Control Module)																																														
CHARGER	2010	ABS (Anti Lock Brake System)	V																																													
CHARGER	2010	ACC (Adaptive Cruise Control)																																														
CHARGER	2010	AHBM (Automatic High Beam)																																														
CHARGER	2010	AMP (Audio)																						V	V																							
CHARGER	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHARGER	2010	DDM (Drivers Door Module)																					V																									
CHARGER	2010	DTCM (Drive Train Control Module)																																														
CHARGER	2010	EOM (Electric Overhead Module)																																											V			
CHARGER	2010	ESM (Electronic Shifter Module)																																														
CHARGER	2010	HFM (Hands Free Module)																																								V						
CHARGER	2010	HSM (Heated Seat Module)																																														
CHARGER	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHARGER	2010	ITM (Intrusion)																																														
CHARGER	2010	LRSM (Light Rain Sensor Module)																																														
CHARGER	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
CHARGER	2010	ORC (Occupant Restraint Control)		V																																												
CHARGER	2010	PDM (Passenger Door Module)																																														
CHARGER	2010	PTS (Park Assist Module)																																														
CHARGER	2010	RADIO (Radio)																																				V	V	V	V							
CHARGER	2010	SCM (Steering Column Module)																																														
CHARGER	2010	SUNR (Sunroof Module)																																														
CHARGER	2010	TCM (Transmission Control Module)																																														
CHARGER	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHARGER	2010	TPM (Tire Pressure Monitor)																																														
CHARGER	2010	VES3 (Vidio Entertainment System 3)																																														
CHARGER	2010	WCM(Wireless Control Modules)														V																											V	V				
CHARGER	2009	PCM (Powertrain Control Module)																																														
CHARGER	2009	ABS (Anti Lock Brake System)	V																																													
CHARGER	2009	ACC (Adaptive Cruise Control)																																														
CHARGER	2009	AHBM (Automatic High Beam)																																														
CHARGER	2009	AMP (Audio)																						V	V																							
CHARGER	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHARGER	2009	DDM (Drivers Door Module)																					V																									
CHARGER	2009	DTCM (Drive Train Control Module)																																														
CHARGER	2009	EOM (Electric Overhead Module)																																											V			
CHARGER	2009	ESM (Electronic Shifter Module)																																														
CHARGER	2009	HFM (Hands Free Module)																																								V						
CHARGER	2009	HSM (Heated Seat Module)																																														
CHARGER	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHARGER	2009	ITM (Intrusion)																																														
CHARGER	2009	LRSM (Light Rain Sensor Module)																																														
CHARGER	2009	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
CHARGER	2009	ORC (Occupant Restraint Control)		V																																												
CHARGER	2009	PDM (Passenger Door Module)																																														
CHARGER	2009	PTS (Park Assist Module)																																														
CHARGER	2009	RADIO (Radio)																																				V	V	V	V							

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CHARGER	2009	SCM (Steering Column Module)																																														
CHARGER	2009	SUNR (Sunroof Module)																																														
CHARGER	2009	TCM (Transmission Control Module)																																														
CHARGER	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHARGER	2009	TPM (Tire Pressure Monitor)																																														
CHARGER	2009	VES3 (Vidio Entertainment System 3)																																														
CHARGER	2009	WCM(Wireless Control Modules)														V																											V	V				
CHARGER	2008	PCM (Powertrain Control Module)																																														
CHARGER	2008	ABS (Anti Lock Brake System)	V																																													
CHARGER	2008	ACC (Adaptive Cruise Control)																																														
CHARGER	2008	AHBM (Automatic High Beam)																																														
CHARGER	2008	AMP (Audio)																						V	V																							
CHARGER	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHARGER	2008	DDM (Drivers Door Module)																					V																										
CHARGER	2008	EOM (Electric Overhead Module)																																											V			
CHARGER	2008	ESM (Electronic Shifter Module)																																														
CHARGER	2008	HFM (Hands Free Module)																																								V						
CHARGER	2008	HSM (Heated Seat Module)																																														
CHARGER	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHARGER	2008	ITM (Intrusion)																																														
CHARGER	2008	LRSM (Light Rain Sensor Module)																																														
CHARGER	2008	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
CHARGER	2008	ORC (Occupant Restraint Control)		V																																												
CHARGER	2008	PDM (Passenger Door Module)																																														
CHARGER	2008	PTS (Park Assist Module)																																														
CHARGER	2008	RADIO (Radio)																																				V	V	V	V							
CHARGER	2008	SCM (Steering Column Module)																																														
CHARGER	2008	SUNR (Sunroof Module)																																														
CHARGER	2008	TCM (Transmission Control Module)																																														
CHARGER	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHARGER	2008	VES3 (Vidio Entertainment System 3)																																														
CHARGER	2008	WCM(Wireless Control Modules)														V																											V	V				
CHARGER	2007	PCM (Powertrain Control Module)																																														
CHARGER	2007	ABS (Anti Lock Brake System)	V																																													
CHARGER	2007	ACC (Adaptive Cruise Control)																																														
CHARGER	2007	AHBM (Automatic High Beam)																																														
CHARGER	2007	AMP (Audio)																						V	V																							
CHARGER	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHARGER	2007	DDM (Drivers Door Module)																					V																										
CHARGER	2007	EOM (Electric Overhead Module)																																											V			
CHARGER	2007	ESM (Electronic Shifter Module)																																														
CHARGER	2007	HFM (Hands Free Module)																																								V						
CHARGER	2007	HSM (Heated Seat Module)																																														
CHARGER	2007	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHARGER	2007	ITM (Intrusion)																																														
CHARGER	2007	LRSM (Light Rain Sensor Module)																																														
CHARGER	2007	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CHARGER	2007	ORC (Occupant Restraint Control)		V																																												
CHARGER	2007	PDM (Passenger Door Module)																																														
CHARGER	2007	PTS (Park Assist Module)																																														
CHARGER	2007	RADIO (Radio)																																				V	V	V	V							
CHARGER	2007	SCM (Steering Column Module)																																														
CHARGER	2007	SDAR (Satellite Radio)																																														
CHARGER	2007	SUNR (Sunroof Module)																																														
CHARGER	2007	TCM (Transmission Control Module)																																														
CHARGER	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHARGER	2007	WCM(Wireless Control Modules)														V																											V	V				
CHARGER	2006	PCM (Powertrain Control Module)																																														
CHARGER	2006	ABS (Anti Lock Brake System)	V																																													
CHARGER	2006	AHBM (Automatic High Beam)																																														
CHARGER	2006	AMP (Audio)																						V	V																							
CHARGER	2006	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHARGER	2006	DDM (Drivers Door Module)																					V																									
CHARGER	2006	EOM (Electric Overhead Module)																																											V			
CHARGER	2006	ESM (Electronic Shifter Module)																																														
CHARGER	2006	HFM (Hands Free Module)																																								V						
CHARGER	2006	HSM (Heated Seat Module)																																														
CHARGER	2006	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHARGER	2006	ITM (Intrusion)																																														
CHARGER	2006	LRSM (Light Rain Sensor Module)																																														
CHARGER	2006	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
CHARGER	2006	OCM (Occupant Classification Module)																																														
CHARGER	2006	ORC (Occupant Restraint Control)		V																																												
CHARGER	2006	PDM (Passenger Door Module)																																														
CHARGER	2006	PTS (Park Assist Module)																																														
CHARGER	2006	RADIO (Radio)																																				V	V	V	V							
CHARGER	2006	SCM (Steering Column Module)																																														
CHARGER	2006	SDAR (Satellite Radio)																																														
CHARGER	2006	SUNR (Sunroof Module)																																														
CHARGER	2006	TCM (Transmission Control Module)																																														
CHARGER	2006	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHARGER	2006	WCM(Wireless Control Modules)														V																											V	V				
CHARGER	2005	PCM (Powertrain Control Module)																																														
CHARGER	2005	ABS (Anti Lock Brake System)	V																																													
CHARGER	2005	AMP (Audio)																						V	V																							
CHARGER	2005	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHARGER	2005	DDM (Drivers Door Module)																					V																									
CHARGER	2005	EOM (Electric Overhead Module)																																											V			
CHARGER	2005	ESM (Electronic Shifter Module)																																														
CHARGER	2005	HFM (Hands Free Module)																																								V						
CHARGER	2005	HSM (Heated Seat Module)																																														
CHARGER	2005	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHARGER	2005	LRSM (Light Rain Sensor Module)																																														
CHARGER	2005	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CHARGER	2005	OCM (Occupant Classification Module)																																														
CHARGER	2005	ORC (Occupant Restraint Control)		V																																												
CHARGER	2005	PDM (Passenger Door Module)																																														
CHARGER	2005	PTS (Park Assist Module)																																														
CHARGER	2005	RADIO (Radio)																																				V	V	V	V							
CHARGER	2005	SCM (Steering Column Module)																																														
CHARGER	2005	SDAR (Satellite Radio)																																														
CHARGER	2005	SUNR (Sunroof Module)																																														
CHARGER	2005	TCM (Transmission Control Module)																																														
CHARGER	2005	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHARGER	2005	WCM(Wireless Control Modules)														V																											V	V				
DAKOTA	2012	PCM (Powertrain Control Module)																																														
DAKOTA	2012	ABS (Anti Lock Brake System)	V																																													
DAKOTA	2012	AMP (Audio)																						V	V																							
DAKOTA	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DAKOTA	2012	EOM (Electric Overhead Module)																																										V				
DAKOTA	2012	HFM (Hands Free Module)																																								V						
DAKOTA	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
DAKOTA	2012	ORC (Occupant Restraint Control)		V																																												
DAKOTA	2012	RADIO (Radio)																																				V	V	V	V							
DAKOTA	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
DAKOTA	2012	WCM(Wireless Control Modules)														V																											V	V				
DAKOTA	2011	PCM (Powertrain Control Module)																																														
DAKOTA	2011	ABS (Anti Lock Brake System)	V																																													
DAKOTA	2011	AMP (Audio)																						V	V																							
DAKOTA	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DAKOTA	2011	EOM (Electric Overhead Module)																																										V				
DAKOTA	2011	HFM (Hands Free Module)																																								V						
DAKOTA	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
DAKOTA	2011	ORC (Occupant Restraint Control)		V																																												
DAKOTA	2011	RADIO (Radio)																																				V	V	V	V							
DAKOTA	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
DAKOTA	2011	WCM(Wireless Control Modules)														V																											V	V				
DAKOTA	2010	PCM (Powertrain Control Module)																																														
DAKOTA	2010	ABS (Anti Lock Brake System)	V																																													
DAKOTA	2010	AMP (Audio)																						V	V																							
DAKOTA	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DAKOTA	2010	EOM (Electric Overhead Module)																																										V				
DAKOTA	2010	HFM (Hands Free Module)																																								V						
DAKOTA	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
DAKOTA	2010	ORC (Occupant Restraint Control)		V																																												
DAKOTA	2010	RADIO (Radio)																																				V	V	V	V							
DAKOTA	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
DAKOTA	2010	WCM(Wireless Control Modules)														V																											V	V				
DAKOTA	2009	PCM (Powertrain Control Module)																																														
DAKOTA	2009	ABS (Anti Lock Brake System)	V																																													
DAKOTA	2009	AMP (Audio)																						V	V																							

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
DAKOTA	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DAKOTA	2009	EOM (Electric Overhead Module)																																										V			
DAKOTA	2009	HFM (Hands Free Module)																																							V						
DAKOTA	2009	HVAC (Heat Vent A/C)																								V	V	V	V																		
DAKOTA	2009	ORC (Occupant Restraint Control)		V																																											
DAKOTA	2009	RADIO (Radio)																																				V	V	V	V						
DAKOTA	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
DAKOTA	2009	WCM(Wireless Control Modules)														V																											V	V			
DAKOTA	2008	PCM (Powertrain Control Module)																																													
DAKOTA	2008	ABS (Anti Lock Brake System)	V																																												
DAKOTA	2008	AMP (Audio)																						V	V																						
DAKOTA	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
DAKOTA	2008	EOM (Electric Overhead Module)																																										V			
DAKOTA	2008	HFM (Hands Free Module)																																							V						
DAKOTA	2008	HVAC (Heat Vent A/C)																								V	V	V	V																		
DAKOTA	2008	ORC (Occupant Restraint Control)		V																																											
DAKOTA	2008	RADIO (Radio)																																				V	V	V	V						
DAKOTA	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
DAKOTA	2008	WCM(Wireless Control Modules)														V																											V	V			
DAKOTA	2007	PCM (Powertrain Control Module)																																													
DAKOTA	2007	ABS (Anti Lock Brake System)	V																																												
DAKOTA	2007	AMP (Audio)																						V	V																						
DAKOTA	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
DAKOTA	2007	EOM (Electric Overhead Module)																																										V			
DAKOTA	2007	HVAC (Heat Vent A/C)																								V	V	V	V																		
DAKOTA	2007	OCM (Occupant Classification Module)																																													
DAKOTA	2007	ORC (Occupant Restraint Control)		V																																											
DAKOTA	2007	RADIO (Radio)																																				V	V	V	V						
DAKOTA	2007	SDAR (Satellite Radio)																																													
DAKOTA	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
DAKOTA	2007	WCM(Wireless Control Modules)														V																											V	V			
DAKOTA	2006	PCM (Powertrain Control Module)																																													
DAKOTA	2006	ABS (Anti Lock Brake System)	V																																												
DAKOTA	2006	AMP (Audio)																						V	V																						
DAKOTA	2006	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
DAKOTA	2006	EOM (Electric Overhead Module)																																										V			
DAKOTA	2006	HFM (Hands Free Module)																																							V						
DAKOTA	2006	HVAC (Heat Vent A/C)																								V	V	V	V																		
DAKOTA	2006	OCM (Occupant Classification Module)																																													
DAKOTA	2006	ORC (Occupant Restraint Control)		V																																											
DAKOTA	2006	RADIO (Radio)																																				V	V	V	V						
DAKOTA	2006	SDAR (Satellite Radio)																																													
DAKOTA	2006	TCM (Transmission Control Module)																																													
DAKOTA	2006	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
DAKOTA	2006	WCM(Wireless Control Modules)														V																											V	V			
DAKOTA	2005	PCM (Powertrain Control Module)																																													
DAKOTA	2005	ABS (Anti Lock Brake System)	V																																												

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
DAKOTA	2005	AMP (Audio)																						V	V																							
DAKOTA	2005	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DAKOTA	2005	EOM (Electric Overhead Module)																																										V				
DAKOTA	2005	HFM (Hands Free Module)																																								V						
DAKOTA	2005	HVAC (Heat Vent A/C)																								V	V	V	V																			
DAKOTA	2005	OCM (Occupant Classification Module)																																														
DAKOTA	2005	ORC (Occupant Restraint Control)		V																																												
DAKOTA	2005	RADIO (Radio)																																				V	V	V	V							
DAKOTA	2005	SDAR (Satellite Radio)																																														
DAKOTA	2005	TCM (Transmission Control Module)																																														
DAKOTA	2005	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
DAKOTA	2005	WCM(Wireless Control Modules)														V																											V	V				
AVENGER	2014	PCM (Powertrain Control Module)																																														
AVENGER	2014	ABS (Anti Lock Brake System)	V																																													
AVENGER	2014	AMP (Audio)																						V	V																							
AVENGER	2014	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
AVENGER	2014	DDM (Drivers Door Module)																					V																									
AVENGER	2014	HFM (Hands Free Module)																																								V						
AVENGER	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
AVENGER	2014	ORC (Occupant Restraint Control)		V																																												
AVENGER	2014	PDM (Passenger Door Module)																																														
AVENGER	2014	RADIO (Radio)																																				V	V	V	V							
AVENGER	2014	SAS (Steering Angle Sensor)																																														
AVENGER	2014	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
AVENGER	2014	WCM(Wireless Control Modules)														V																											V	V				
AVENGER	2013	PCM (Powertrain Control Module)																																														
AVENGER	2013	ABS (Anti Lock Brake System)	V																																													
AVENGER	2013	AMP (Audio)																						V	V																							
AVENGER	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
AVENGER	2013	DDM (Drivers Door Module)																					V																									
AVENGER	2013	HFM (Hands Free Module)																																								V						
AVENGER	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
AVENGER	2013	ORC (Occupant Restraint Control)		V																																												
AVENGER	2013	PDM (Passenger Door Module)																																														
AVENGER	2013	RADIO (Radio)																																				V	V	V	V							
AVENGER	2013	SAS (Steering Angle Sensor)																																														
AVENGER	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
AVENGER	2013	WCM(Wireless Control Modules)														V																											V	V				
AVENGER	2012	PCM (Powertrain Control Module)																																														
AVENGER	2012	ABS (Anti Lock Brake System)	V																																													
AVENGER	2012	AMP (Audio)																						V	V																							
AVENGER	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
AVENGER	2012	DDM (Drivers Door Module)																					V																									
AVENGER	2012	HFM (Hands Free Module)																																								V						
AVENGER	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
AVENGER	2012	ORC (Occupant Restraint Control)		V																																												
AVENGER	2012	PDM (Passenger Door Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
AVENGER	2012	RADIO (Radio)																																				V	V	V	V						
AVENGER	2012	SAS (Steering Angle Sensor)																																														
AVENGER	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
AVENGER	2012	WCM(Wireless Control Modules)														V																												V	V			
AVENGER	2011	PCM (Powertrain Control Module)																																														
AVENGER	2011	ABS (Anti Lock Brake System)	V																																													
AVENGER	2011	AMP (Audio)																						V	V																							
AVENGER	2011	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
AVENGER	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
AVENGER	2011	DDM (Drivers Door Module)																					V																									
AVENGER	2011	ESM (Electronic Shifter Module)																																														
AVENGER	2011	HFM (Hands Free Module)																																								V						
AVENGER	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
AVENGER	2011	ITM (Intrusion)																																														
AVENGER	2011	ORC (Occupant Restraint Control)		V																																												
AVENGER	2011	PDM (Passenger Door Module)																																														
AVENGER	2011	RADIO (Radio)																																				V	V	V	V						
AVENGER	2011	SAS (Steering Angle Sensor)																																														
AVENGER	2011	TCM (Transmission Control Module)																																														
AVENGER	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
AVENGER	2011	VES3 (Vidio Entertainment System 3)																																														
AVENGER	2011	WCM(Wireless Control Modules)														V																												V	V			
AVENGER	2010	PCM (Powertrain Control Module)																																														
AVENGER	2010	ABS (Anti Lock Brake System)	V																																													
AVENGER	2010	AMP (Audio)																						V	V																							
AVENGER	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
AVENGER	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
AVENGER	2010	DDM (Drivers Door Module)																					V																									
AVENGER	2010	HFM (Hands Free Module)																																								V						
AVENGER	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
AVENGER	2010	ITM (Intrusion)																																														
AVENGER	2010	ORC (Occupant Restraint Control)		V																																												
AVENGER	2010	PDM (Passenger Door Module)																																														
AVENGER	2010	RADIO (Radio)																																				V	V	V	V						
AVENGER	2010	SAS (Steering Angle Sensor)																																														
AVENGER	2010	TCM (Transmission Control Module)																																														
AVENGER	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
AVENGER	2010	VES3 (Vidio Entertainment System 3)																																														
AVENGER	2010	WCM(Wireless Control Modules)														V																												V	V			
AVENGER	2009	PCM (Powertrain Control Module)																																														
AVENGER	2009	ABS (Anti Lock Brake System)	V																																													
AVENGER	2009	AMP (Audio)																						V	V																							
AVENGER	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
AVENGER	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
AVENGER	2009	DDM (Drivers Door Module)																					V																									
AVENGER	2009	HFM (Hands Free Module)																																								V						
AVENGER	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
AVENGER	2009	ITM (Intrusion)																																														
AVENGER	2009	ORC (Occupant Restraint Control)		V																																												
AVENGER	2009	PDM (Passenger Door Module)																																														
AVENGER	2009	RADIO (Radio)																																				V	V	V	V							
AVENGER	2009	SAS (Steering Angle Sensor)																																														
AVENGER	2009	TCM (Transmission Control Module)																																														
AVENGER	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
AVENGER	2009	VES3 (Vidio Entertainment System 3)																																														
AVENGER	2009	WCM(Wireless Control Modules)														V																											V	V				
AVENGER	2008	PCM (Powertrain Control Module)																																														
AVENGER	2008	ABS (Anti Lock Brake System)	V																																													
AVENGER	2008	AMP (Audio)																						V	V																							
AVENGER	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
AVENGER	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
AVENGER	2008	DDM (Drivers Door Module)																					V																									
AVENGER	2008	HFM (Hands Free Module)																																								V						
AVENGER	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
AVENGER	2008	ITM (Intrusion)																																														
AVENGER	2008	ORC (Occupant Restraint Control)		V																																												
AVENGER	2008	PDM (Passenger Door Module)																																														
AVENGER	2008	RADIO (Radio)																																				V	V	V	V							
AVENGER	2008	SAS (Steering Angle Sensor)																																														
AVENGER	2008	TCM (Transmission Control Module)																																														
AVENGER	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
AVENGER	2008	VES3 (Vidio Entertainment System 3)																																														
AVENGER	2008	WCM(Wireless Control Modules)														V																											V	V				
AVENGER	2007	PCM (Powertrain Control Module)																																														
AVENGER	2007	ABS (Anti Lock Brake System)	V																																													
AVENGER	2007	AMP (Audio)																						V	V																							
AVENGER	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
AVENGER	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
AVENGER	2007	DDM (Drivers Door Module)																					V																									
AVENGER	2007	HFM (Hands Free Module)																																								V						
AVENGER	2007	HVAC (Heat Vent A/C)																								V	V	V	V																			
AVENGER	2007	ITM (Intrusion)																																														
AVENGER	2007	ORC (Occupant Restraint Control)		V																																												
AVENGER	2007	PDM (Passenger Door Module)																																														
AVENGER	2007	RADIO (Radio)																																				V	V	V	V							
AVENGER	2007	SAS (Steering Angle Sensor)																																														
AVENGER	2007	TCM (Transmission Control Module)																																														
AVENGER	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
AVENGER	2007	VES3 (Vidio Entertainment System 3)																																														
AVENGER	2007	WCM(Wireless Control Modules)														V																											V	V				
NITRO	2012	PCM (Powertrain Control Module)																																														
NITRO	2012	ABS (Anti Lock Brake System)	V																																													
NITRO	2012	AMP (Audio)																						V	V																							
NITRO	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
NITRO	2012	ESM (Electronic Shifter Module)																																													
NITRO	2012	HFM (Hands Free Module)																																							V					
NITRO	2012	HVAC (Heat Vent A/C)																								V	V	V	V																	
NITRO	2012	ITM (Intrusion)																																												
NITRO	2012	OCM (Occupant Classification Module)																																												
NITRO	2012	ORC (Occupant Restraint Control)		V																																										
NITRO	2012	PTS (Park Assist Module)																																												
NITRO	2012	RADIO (Radio)																																				V	V	V	V					
NITRO	2012	SAS (Steering Angle Sensor)																																												
NITRO	2012	TCM (Transmission Control Module)																																												
NITRO	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																															
NITRO	2012	WCM(Wireless Control Modules)														V																											V	V			
NITRO	2011	PCM (Powertrain Control Module)																																												
NITRO	2011	ABS (Anti Lock Brake System)	V																																											
NITRO	2011	AMP (Audio)																						V	V																					
NITRO	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																								
NITRO	2011	ESM (Electronic Shifter Module)																																												
NITRO	2011	HFM (Hands Free Module)																																							V					
NITRO	2011	HVAC (Heat Vent A/C)																								V	V	V	V																	
NITRO	2011	ITM (Intrusion)																																												
NITRO	2011	OCM (Occupant Classification Module)																																												
NITRO	2011	ORC (Occupant Restraint Control)		V																																										
NITRO	2011	PTS (Park Assist Module)																																												
NITRO	2011	RADIO (Radio)																																				V	V	V	V					
NITRO	2011	SAS (Steering Angle Sensor)																																												
NITRO	2011	TCM (Transmission Control Module)																																												
NITRO	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																															
NITRO	2011	WCM(Wireless Control Modules)														V																											V	V			
NITRO	2010	PCM (Powertrain Control Module)																																												
NITRO	2010	ABS (Anti Lock Brake System)	V																																											
NITRO	2010	AMP (Audio)																						V	V																					
NITRO	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																								
NITRO	2010	ESM (Electronic Shifter Module)																																												
NITRO	2010	HFM (Hands Free Module)																																							V					
NITRO	2010	HVAC (Heat Vent A/C)																								V	V	V	V																	
NITRO	2010	ITM (Intrusion)																																												
NITRO	2010	OCM (Occupant Classification Module)																																												
NITRO	2010	ORC (Occupant Restraint Control)		V																																										
NITRO	2010	PTS (Park Assist Module)																																												
NITRO	2010	RADIO (Radio)																																				V	V	V	V					
NITRO	2010	SAS (Steering Angle Sensor)																																												
NITRO	2010	TCM (Transmission Control Module)																																												
NITRO	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																															
NITRO	2010	WCM(Wireless Control Modules)														V																											V	V			
NITRO	2009	PCM (Powertrain Control Module)																																												
NITRO	2009	ABS (Anti Lock Brake System)	V																																											
NITRO	2009	AMP (Audio)																						V	V																					

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
NITRO	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
NITRO	2009	ESM (Electronic Shifter Module)																																														
NITRO	2009	HFM (Hands Free Module)																																								V						
NITRO	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
NITRO	2009	ITM (Intrusion)																																														
NITRO	2009	OCM (Occupant Classification Module)																																														
NITRO	2009	ORC (Occupant Restraint Control)		V																																												
NITRO	2009	PTS (Park Assist Module)																																														
NITRO	2009	RADIO (Radio)																																				V	V	V	V							
NITRO	2009	SAS (Steering Angle Sensor)																																														
NITRO	2009	TCM (Transmission Control Module)																																														
NITRO	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
NITRO	2009	VES3 (Vidio Entertainment System 3)																																														
NITRO	2009	WCM(Wireless Control Modules)														V																											V	V				
NITRO	2008	PCM (Powertrain Control Module)																																														
NITRO	2008	ABS (Anti Lock Brake System)	V																																													
NITRO	2008	AMP (Audio)																						V	V																							
NITRO	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
NITRO	2008	ESM (Electronic Shifter Module)																																														
NITRO	2008	HFM (Hands Free Module)																																								V						
NITRO	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
NITRO	2008	ITM (Intrusion)																																														
NITRO	2008	OCM (Occupant Classification Module)																																														
NITRO	2008	ORC (Occupant Restraint Control)		V																																												
NITRO	2008	PTS (Park Assist Module)																																														
NITRO	2008	RADIO (Radio)																																				V	V	V	V							
NITRO	2008	SAS (Steering Angle Sensor)																																														
NITRO	2008	TCM (Transmission Control Module)																																														
NITRO	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
NITRO	2008	VES3 (Vidio Entertainment System 3)																																														
NITRO	2008	WCM(Wireless Control Modules)														V																											V	V				
NITRO	2007	PCM (Powertrain Control Module)																																														
NITRO	2007	ABS (Anti Lock Brake System)	V																																													
NITRO	2007	AMP (Audio)																						V	V																							
NITRO	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
NITRO	2007	ESM (Electronic Shifter Module)																																														
NITRO	2007	HFM (Hands Free Module)																																								V						
NITRO	2007	HVAC (Heat Vent A/C)																								V	V	V	V																			
NITRO	2007	ITM (Intrusion)																																														
NITRO	2007	OCM (Occupant Classification Module)																																														
NITRO	2007	ORC (Occupant Restraint Control)		V																																												
NITRO	2007	PTS (Park Assist Module)																																														
NITRO	2007	RADIO (Radio)																																				V	V	V	V							
NITRO	2007	SAS (Steering Angle Sensor)																																														
NITRO	2007	TCM (Transmission Control Module)																																														
NITRO	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
NITRO	2007	VES3 (Vidio Entertainment System 3)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
NITRO	2007	WCM(Wireless Control Modules)														V																												V	V			
CLIBER	2012	PCM (Powertrain Control Module)																																														
CLIBER	2012	ABS (Anti Lock Brake System)	V																																													
CLIBER	2012	AMP (Audio)																						V	V																							
CLIBER	2012	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
CLIBER	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CLIBER	2012	HFM (Hands Free Module)																																								V						
CLIBER	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
CLIBER	2012	ITM (Intrusion)																																														
CLIBER	2012	ORC (Occupant Restraint Control)		V																																												
CLIBER	2012	RADIO (Radio)																																				V	V	V	V							
CLIBER	2012	SAS (Steering Angle Sensor)																																														
CLIBER	2012	TCM (Transmission Control Module)																																														
CLIBER	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
CLIBER	2012	WCM(Wireless Control Modules)														V																												V	V			
CLIBER	2011	PCM (Powertrain Control Module)																																														
CLIBER	2011	ABS (Anti Lock Brake System)	V																																													
CLIBER	2011	AMP (Audio)																						V	V																							
CLIBER	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CLIBER	2011	HFM (Hands Free Module)																																								V						
CLIBER	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
CLIBER	2011	ITM (Intrusion)																																														
CLIBER	2011	ORC (Occupant Restraint Control)		V																																												
CLIBER	2011	RADIO (Radio)																																				V	V	V	V							
CLIBER	2011	SAS (Steering Angle Sensor)																																														
CLIBER	2011	TCM (Transmission Control Module)																																														
CLIBER	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
CLIBER	2011	WCM(Wireless Control Modules)														V																												V	V			
CLIBER	2010	PCM (Powertrain Control Module)																																														
CLIBER	2010	ABS (Anti Lock Brake System)	V																																													
CLIBER	2010	AMP (Audio)																						V	V																							
CLIBER	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
CLIBER	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CLIBER	2010	HFM (Hands Free Module)																																								V						
CLIBER	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
CLIBER	2010	ITM (Intrusion)																																														
CLIBER	2010	ORC (Occupant Restraint Control)		V																																												
CLIBER	2010	RADIO (Radio)																																				V	V	V	V							
CLIBER	2010	SAS (Steering Angle Sensor)																																														
CLIBER	2010	TCM (Transmission Control Module)																																														
CLIBER	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
CLIBER	2010	WCM(Wireless Control Modules)														V																												V	V			
CLIBER	2009	PCM (Powertrain Control Module)																																														
CLIBER	2009	ABS (Anti Lock Brake System)	V																																													
CLIBER	2009	AMP (Audio)																						V	V																							
CLIBER	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
CLIBER	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CLIBER	2009	HFM (Hands Free Module)																																								V						
CLIBER	2009	ITM (Intrusion)																																														
CLIBER	2009	ORC (Occupant Restraint Control)		V																																												
CLIBER	2009	RADIO (Radio)																																				V	V	V	V							
CLIBER	2009	SAS (Steering Angle Sensor)																																														
CLIBER	2009	TCM (Transmission Control Module)																																														
CLIBER	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CLIBER	2009	WCM(Wireless Control Modules)														V																											V	V				
CLIBER	2008	PCM (Powertrain Control Module)																																														
CLIBER	2008	ABS (Anti Lock Brake System)	V																																													
CLIBER	2008	AMP (Audio)																						V	V																							
CLIBER	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
CLIBER	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CLIBER	2008	HFM (Hands Free Module)																																								V						
CLIBER	2008	ITM (Intrusion)																																														
CLIBER	2008	OCM (Occupant Classification Module)																																														
CLIBER	2008	ORC (Occupant Restraint Control)		V																																												
CLIBER	2008	RADIO (Radio)																																				V	V	V	V							
CLIBER	2008	SAS (Steering Angle Sensor)																																														
CLIBER	2008	SDAR (Satellite Radio)																																														
CLIBER	2008	TCM (Transmission Control Module)																																														
CLIBER	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CLIBER	2008	WCM(Wireless Control Modules)														V																											V	V				
CLIBER	2007	PCM (Powertrain Control Module)																																														
CLIBER	2007	ABS (Anti Lock Brake System)	V																																													
CLIBER	2007	AMP (Audio)																						V	V																							
CLIBER	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
CLIBER	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CLIBER	2007	HFM (Hands Free Module)																																								V						
CLIBER	2007	ITM (Intrusion)																																														
CLIBER	2007	OCM (Occupant Classification Module)																																														
CLIBER	2007	ORC (Occupant Restraint Control)		V																																												
CLIBER	2007	RADIO (Radio)																																				V	V	V	V							
CLIBER	2007	SAS (Steering Angle Sensor)																																														
CLIBER	2007	SDAR (Satellite Radio)																																														
CLIBER	2007	TCM (Transmission Control Module)																																														
CLIBER	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CLIBER	2007	WCM(Wireless Control Modules)														V																											V	V				
SPRINTER	2009	PCM (Powertrain Control Module)																																														
SPRINTER	2009	ABS (Anti Lock Brake System)	V																																													
SPRINTER	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
SPRINTER	2009	DDM (Drivers Door Module)																					V																									
SPRINTER	2009	ESM (Electronic Shifter Module)																																														
SPRINTER	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
SPRINTER	2009	ORC (Occupant Restraint Control)		V																																												
SPRINTER	2009	PTS (Park Assist Module)																																														
SPRINTER	2009	RADIO (Radio)																																				V	V	V	V							

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
SPRINTER	2009	SCM (Steering Column Module)																																													
SPRINTER	2009	TCM (Transmission Control Module)																																													
SPRINTER	2009	TPM (Tire Pressure Monitor)																																													
SPRINTER	2008	PCM (Powertrain Control Module)																																													
SPRINTER	2008	ABS (Anti Lock Brake System)	V																																												
SPRINTER	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
SPRINTER	2008	DDM (Drivers Door Module)																					V																								
SPRINTER	2008	ESM (Electronic Shifter Module)																																													
SPRINTER	2008	HVAC (Heat Vent A/C)																								V	V	V	V																		
SPRINTER	2008	ORC (Occupant Restraint Control)		V																																											
SPRINTER	2008	PTS (Park Assist Module)																																													
SPRINTER	2008	RADIO (Radio)																																				V	V	V	V						
SPRINTER	2008	SCM (Steering Column Module)																																													
SPRINTER	2008	TCM (Transmission Control Module)																																													
SPRINTER	2008	TPM (Tire Pressure Monitor)																																													
SPRINTER	2007	PCM (Powertrain Control Module)																																													
SPRINTER	2007	ABS (Anti Lock Brake System)	V																																												
SPRINTER	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
SPRINTER	2007	DDM (Drivers Door Module)																					V																								
SPRINTER	2007	ESM (Electronic Shifter Module)																																													
SPRINTER	2007	HVAC (Heat Vent A/C)																								V	V	V	V																		
SPRINTER	2007	ORC (Occupant Restraint Control)		V																																											
SPRINTER	2007	PTS (Park Assist Module)																																													
SPRINTER	2007	RADIO (Radio)																																				V	V	V	V						
SPRINTER	2007	SCM (Steering Column Module)																																													
SPRINTER	2007	TCM (Transmission Control Module)																																													
SPRINTER	2007	TPM (Tire Pressure Monitor)																																													
CROSSFIRE	2008	PCM (Powertrain Control Module)																																													
CROSSFIRE	2008	OCM (Occupant Classification Module)																																													
CROSSFIRE	2008	ORC (Occupant Restraint Control)		V																																											
CROSSFIRE	2007	PCM (Powertrain Control Module)																																													
CROSSFIRE	2007	OCM (Occupant Classification Module)																																													
CROSSFIRE	2007	ORC (Occupant Restraint Control)		V																																											
JOURNEY	2016	PCM (Powertrain Control Module)																																													
JOURNEY	2016	ABS (Anti Lock Brake System)																																													
JOURNEY	2016	AMP (Audio)																																													
JOURNEY	2016	BCM (Body Control Module)																																													
JOURNEY	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																													
JOURNEY	2016	CGW (Central Gateway)																																													
JOURNEY	2016	DDM (Drivers Door Module)																																													
JOURNEY	2016	DTCM (Drive Train Control Module)																																													
JOURNEY	2016	HFM (Hands Free Module)																																													
JOURNEY	2016	HSM (Heated Seat Module)																																													
JOURNEY	2016	HVAC (Heat Vent A/C)																																													
JOURNEY	2016	ICS (Integrated Center Stack)																																													
JOURNEY	2016	IPC (Instrument Panel Cluster)																																													
JOURNEY	2016	ITM (Intrusion)																																													

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
JOURNEY	2016	ORC (Occupant Restraint Control)																																														
JOURNEY	2016	PDM (Passenger Door Module)																																														
JOURNEY	2016	PTS (Park Assist Module)																																														
JOURNEY	2016	RBSS (Right Blind Spot Sensor)																																														
JOURNEY	2016	RFH (Radio Frequency Hub)																																														
JOURNEY	2016	SCM (Steering Column Module)																																														
JOURNEY	2016	TCM (Transmission Control Module)																																														
JOURNEY	2016	TGW (Telematics Gateway)																																														
JOURNEY	2016	TPM (Tire Pressure Monitor)																																														
JOURNEY	2016	VES3 (Vidio Entertainment System 3)																																														
JOURNEY	2016	WCM(Wireless Control Modules)																																														
JOURNEY	2015	PCM (Powertrain Control Module)																																														
JOURNEY	2015	ABS (Anti Lock Brake System)																																														
JOURNEY	2015	AMP (Audio)																																														
JOURNEY	2015	BCM (Body Control Module)																																														
JOURNEY	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
JOURNEY	2015	CGW (Central Gateway)																																														
JOURNEY	2015	DDM (Drivers Door Module)																																														
JOURNEY	2015	DTCM (Drive Train Control Module)																																														
JOURNEY	2015	HFM (Hands Free Module)																																														
JOURNEY	2015	HSM (Heated Seat Module)																																														
JOURNEY	2015	HVAC (Heat Vent A/C)																																														
JOURNEY	2015	ICS (Integrated Center Stack)																																														
JOURNEY	2015	IPC (Instrument Panel Cluster)																																														
JOURNEY	2015	ITM (Intrusion)																																														
JOURNEY	2015	ORC (Occupant Restraint Control)																																														
JOURNEY	2015	PDM (Passenger Door Module)																																														
JOURNEY	2015	PTS (Park Assist Module)																																														
JOURNEY	2015	RBSS (Right Blind Spot Sensor)																																														
JOURNEY	2015	RFH (Radio Frequency Hub)																																														
JOURNEY	2015	SCM (Steering Column Module)																																														
JOURNEY	2015	TCM (Transmission Control Module)																																														
JOURNEY	2015	TGW (Telematics Gateway)																																														
JOURNEY	2015	TPM (Tire Pressure Monitor)																																														
JOURNEY	2015	VES3 (Vidio Entertainment System 3)																																														
JOURNEY	2015	WCM(Wireless Control Modules)																																														
JOURNEY	2014	PCM (Powertrain Control Module)																																														
JOURNEY	2014	ABS (Anti Lock Brake System)	V																																													
JOURNEY	2014	AMP (Audio)																						V	V																							
JOURNEY	2014	DDM (Drivers Door Module)																					V																									
JOURNEY	2014	DTCM (Drive Train Control Module)																																														
JOURNEY	2014	HFM (Hands Free Module)																																								V						
JOURNEY	2014	HSM (Heated Seat Module)																																														
JOURNEY	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
JOURNEY	2014	ITM (Intrusion)																																														
JOURNEY	2014	ORC (Occupant Restraint Control)		V																																												
JOURNEY	2014	PDM (Passenger Door Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
JOURNEY	2014	PTS (Park Assist Module)																																													
JOURNEY	2014	TCM (Transmission Control Module)																																													
JOURNEY	2014	TPM (Tire Pressure Monitor)																																													
JOURNEY	2014	VES3 (Vidio Entertainment System 3)																																													
JOURNEY	2013	PCM (Powertrain Control Module)																																													
JOURNEY	2013	ABS (Anti Lock Brake System)	V																																												
JOURNEY	2013	AMP (Audio)																						V	V																						
JOURNEY	2013	DDM (Drivers Door Module)																					V																								
JOURNEY	2013	DTCM (Drive Train Control Module)																																													
JOURNEY	2013	HFM (Hands Free Module)																																							V						
JOURNEY	2013	HSM (Heated Seat Module)																																													
JOURNEY	2013	HVAC (Heat Vent A/C)																								V	V	V	V																		
JOURNEY	2013	ITM (Intrusion)																																													
JOURNEY	2013	ORC (Occupant Restraint Control)		V																																											
JOURNEY	2013	PDM (Passenger Door Module)																																													
JOURNEY	2013	PTS (Park Assist Module)																																													
JOURNEY	2013	TCM (Transmission Control Module)																																													
JOURNEY	2013	TPM (Tire Pressure Monitor)																																													
JOURNEY	2013	VES3 (Vidio Entertainment System 3)																																													
JOURNEY	2012	PCM (Powertrain Control Module)																																													
JOURNEY	2012	ABS (Anti Lock Brake System)	V																																												
JOURNEY	2012	AMP (Audio)																						V	V																						
JOURNEY	2012	DDM (Drivers Door Module)																					V																								
JOURNEY	2012	DTCM (Drive Train Control Module)																																													
JOURNEY	2012	HFM (Hands Free Module)																																							V						
JOURNEY	2012	HSM (Heated Seat Module)																																													
JOURNEY	2012	HVAC (Heat Vent A/C)																								V	V	V	V																		
JOURNEY	2012	ITM (Intrusion)																																													
JOURNEY	2012	ORC (Occupant Restraint Control)		V																																											
JOURNEY	2012	PDM (Passenger Door Module)																																													
JOURNEY	2012	PTS (Park Assist Module)																																													
JOURNEY	2012	TCM (Transmission Control Module)																																													
JOURNEY	2012	TPM (Tire Pressure Monitor)																																													
JOURNEY	2012	VES3 (Vidio Entertainment System 3)																																													
JOURNEY	2011	PCM (Powertrain Control Module)																																													
JOURNEY	2011	ABS (Anti Lock Brake System)	V																																												
JOURNEY	2011	AMP (Audio)																						V	V																						
JOURNEY	2011	DDM (Drivers Door Module)																					V																								
JOURNEY	2011	DTCM (Drive Train Control Module)																																													
JOURNEY	2011	HFM (Hands Free Module)																																							V						
JOURNEY	2011	HSM (Heated Seat Module)																																													
JOURNEY	2011	HVAC (Heat Vent A/C)																								V	V	V	V																		
JOURNEY	2011	ITM (Intrusion)																																													
JOURNEY	2011	ORC (Occupant Restraint Control)		V																																											
JOURNEY	2011	PDM (Passenger Door Module)																																													
JOURNEY	2011	PTS (Park Assist Module)																																													
JOURNEY	2011	TPM (Tire Pressure Monitor)																																													

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
JOURNEY	2011	VES3 (Vidio Entertainment System 3)																																														
JOURNEY	2010	PCM (Powertrain Control Module)																																														
JOURNEY	2010	ABS (Anti Lock Brake System)	V																																													
JOURNEY	2010	AMP (Audio)																						V	V																							
JOURNEY	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
JOURNEY	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
JOURNEY	2010	HFM (Hands Free Module)																																								V						
JOURNEY	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
JOURNEY	2010	ITM (Intrusion)																																														
JOURNEY	2010	ORC (Occupant Restraint Control)		V																																												
JOURNEY	2010	RADIO (Radio)																																				V	V	V	V							
JOURNEY	2010	SAS (Steering Angle Sensor)																																														
JOURNEY	2010	TCM (Transmission Control Module)																																														
JOURNEY	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
JOURNEY	2010	VES3 (Vidio Entertainment System 3)																																														
JOURNEY	2010	WCM(Wireless Control Modules)														V																											V	V				
JOURNEY	2009	PCM (Powertrain Control Module)																																														
JOURNEY	2009	ABS (Anti Lock Brake System)	V																																													
JOURNEY	2009	AMP (Audio)																						V	V																							
JOURNEY	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
JOURNEY	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
JOURNEY	2009	HFM (Hands Free Module)																																								V						
JOURNEY	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
JOURNEY	2009	ITM (Intrusion)																																														
JOURNEY	2009	ORC (Occupant Restraint Control)		V																																												
JOURNEY	2009	RADIO (Radio)																																				V	V	V	V							
JOURNEY	2009	SAS (Steering Angle Sensor)																																														
JOURNEY	2009	TCM (Transmission Control Module)																																														
JOURNEY	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
JOURNEY	2009	VES3 (Vidio Entertainment System 3)																																														
JOURNEY	2009	WCM(Wireless Control Modules)														V																											V	V				
JOURNEY	2008	PCM (Powertrain Control Module)																																														
JOURNEY	2008	ABS (Anti Lock Brake System)	V																																													
JOURNEY	2008	AMP (Audio)																						V	V																							
JOURNEY	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
JOURNEY	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
JOURNEY	2008	HFM (Hands Free Module)																																								V						
JOURNEY	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
JOURNEY	2008	ITM (Intrusion)																																														
JOURNEY	2008	ORC (Occupant Restraint Control)		V																																												
JOURNEY	2008	RADIO (Radio)																																				V	V	V	V							
JOURNEY	2008	SAS (Steering Angle Sensor)																																														
JOURNEY	2008	TCM (Transmission Control Module)																																														
JOURNEY	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
JOURNEY	2008	VES3 (Vidio Entertainment System 3)																																														
JOURNEY	2008	WCM(Wireless Control Modules)														V																											V	V				
CHALLENGER	2016	PCM (Powertrain Control Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CHALLENGER	2016	ABS (Anti Lock Brake System)																																														
CHALLENGER	2016	ACC (Adaptive Cruise Control)																																														
CHALLENGER	2016	ADCM (Adaptive Damper Control Module)																																														
CHALLENGER	2016	AMP (Audio)																																														
CHALLENGER	2016	BCM (Body Control Module)																																														
CHALLENGER	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
CHALLENGER	2016	CGW (Central Gateway)																																														
CHALLENGER	2016	DDM (Drivers Door Module)																																														
CHALLENGER	2016	EPS (Electric Power Steering)																																														
CHALLENGER	2016	ESM (Electronic Shifter Module)																																														
CHALLENGER	2016	HSM (Heated Seat Module)																																														
CHALLENGER	2016	HVAC (Heat Vent A/C)																																														
CHALLENGER	2016	ICS (Integrated Center Stack)																																														
CHALLENGER	2016	IPC (Instrument Panel Cluster)																																														
CHALLENGER	2016	LBSS (Left Blind Spot Sensor)																																														
CHALLENGER	2016	MSMD (Memory Seet Module)																																														
CHALLENGER	2016	ORC (Occupant Restraint Control)																																														
CHALLENGER	2016	PDM (Passenger Door Module)																																														
CHALLENGER	2016	PTS (Park Assist Module)																																														
CHALLENGER	2016	RADIO (Radio)																																														
CHALLENGER	2016	RBSS (Right Blind Spot Sensor)																																														
CHALLENGER	2016	RFH (Radio Frequency Hub)																																														
CHALLENGER	2016	SCM (Steering Column Module)																																														
CHALLENGER	2016	TCM (Transmission Control Module)																																														
CHALLENGER	2016	TPM (Tire Pressure Monitor)																																														
CHALLENGER	2016	WCM(Wireless Control Modules)																																														
CHALLENGER	2015	PCM (Powertrain Control Module)																																														
CHALLENGER	2015	ABS (Anti Lock Brake System)																																														
CHALLENGER	2015	ACC (Adaptive Cruise Control)																																														
CHALLENGER	2015	ADCM (Adaptive Damper Control Module)																																														
CHALLENGER	2015	AMP (Audio)																																														
CHALLENGER	2015	BCM (Body Control Module)																																														
CHALLENGER	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
CHALLENGER	2015	CGW (Central Gateway)																																														
CHALLENGER	2015	DDM (Drivers Door Module)																																														
CHALLENGER	2015	EPS (Electric Power Steering)																																														
CHALLENGER	2015	ESM (Electronic Shifter Module)																																														
CHALLENGER	2015	HSM (Heated Seat Module)																																														
CHALLENGER	2015	HVAC (Heat Vent A/C)																																														
CHALLENGER	2015	ICS (Integrated Center Stack)																																														
CHALLENGER	2015	IPC (Instrument Panel Cluster)																																														
CHALLENGER	2015	LBSS (Left Blind Spot Sensor)																																														
CHALLENGER	2015	MSMD (Memory Seet Module)																																														
CHALLENGER	2015	ORC (Occupant Restraint Control)																																														
CHALLENGER	2015	PDM (Passenger Door Module)																																														
CHALLENGER	2015	PTS (Park Assist Module)																																														
CHALLENGER	2015	RADIO (Radio)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CHALLENGER	2015	RBSS (Right Blind Spot Sensor)																																														
CHALLENGER	2015	RFH (Radio Frequency Hub)																																														
CHALLENGER	2015	SCM (Steering Column Module)																																														
CHALLENGER	2015	TCM (Transmission Control Module)																																														
CHALLENGER	2015	TPM (Tire Pressure Monitor)																																														
CHALLENGER	2015	WCM(Wireless Control Modules)																																														
CHALLENGER	2014	PCM (Powertrain Control Module)																																														
CHALLENGER	2014	ABS (Anti Lock Brake System)	V																																													
CHALLENGER	2014	AMP (Audio)																						V	V																							
CHALLENGER	2014	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHALLENGER	2014	DDM (Drivers Door Module)																					V																										
CHALLENGER	2014	EOM (Electric Overhead Module)																																											V			
CHALLENGER	2014	ESM (Electronic Shifter Module)																																														
CHALLENGER	2014	HFM (Hands Free Module)																																								V						
CHALLENGER	2014	HSM (Heated Seat Module)																																														
CHALLENGER	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHALLENGER	2014	ORC (Occupant Restraint Control)		V																																												
CHALLENGER	2014	PDM (Passenger Door Module)																																														
CHALLENGER	2014	PTS (Park Assist Module)																																														
CHALLENGER	2014	RADIO (Radio)																																				V	V	V	V							
CHALLENGER	2014	SAS (Steering Angle Sensor)																																														
CHALLENGER	2014	SUNR (Sunroof Module)																																														
CHALLENGER	2014	TCM (Transmission Control Module)																																														
CHALLENGER	2014	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHALLENGER	2014	TPM (Tire Pressure Monitor)																																														
CHALLENGER	2014	WCM(Wireless Control Modules)														V																											V	V				
CHALLENGER	2013	PCM (Powertrain Control Module)																																														
CHALLENGER	2013	ABS (Anti Lock Brake System)	V																																													
CHALLENGER	2013	AMP (Audio)																						V	V																							
CHALLENGER	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHALLENGER	2013	DDM (Drivers Door Module)																					V																										
CHALLENGER	2013	EOM (Electric Overhead Module)																																											V			
CHALLENGER	2013	ESM (Electronic Shifter Module)																																														
CHALLENGER	2013	HFM (Hands Free Module)																																								V						
CHALLENGER	2013	HSM (Heated Seat Module)																																														
CHALLENGER	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHALLENGER	2013	ORC (Occupant Restraint Control)		V																																												
CHALLENGER	2013	PDM (Passenger Door Module)																																														
CHALLENGER	2013	PTS (Park Assist Module)																																														
CHALLENGER	2013	RADIO (Radio)																																				V	V	V	V							
CHALLENGER	2013	SAS (Steering Angle Sensor)																																														
CHALLENGER	2013	SUNR (Sunroof Module)																																														
CHALLENGER	2013	TCM (Transmission Control Module)																																														
CHALLENGER	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHALLENGER	2013	TPM (Tire Pressure Monitor)																																														
CHALLENGER	2013	WCM(Wireless Control Modules)														V																											V	V				
CHALLENGER	2012	PCM (Powertrain Control Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CHALLENGER	2012	ABS (Anti Lock Brake System)	V																																													
CHALLENGER	2012	AMP (Audio)																						V	V																							
CHALLENGER	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHALLENGER	2012	DDM (Drivers Door Module)																					V																									
CHALLENGER	2012	EOM (Electric Overhead Module)																																										V				
CHALLENGER	2012	ESM (Electronic Shifter Module)																																														
CHALLENGER	2012	HFM (Hands Free Module)																																								V						
CHALLENGER	2012	HSM (Heated Seat Module)																																														
CHALLENGER	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHALLENGER	2012	ORC (Occupant Restraint Control)		V																																												
CHALLENGER	2012	PDM (Passenger Door Module)																																														
CHALLENGER	2012	RADIO (Radio)																																				V	V	V	V							
CHALLENGER	2012	SAS (Steering Angle Sensor)																																														
CHALLENGER	2012	SUNR (Sunroof Module)																																														
CHALLENGER	2012	TCM (Transmission Control Module)																																														
CHALLENGER	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHALLENGER	2012	TPM (Tire Pressure Monitor)																																														
CHALLENGER	2012	WCM(Wireless Control Modules)														V																											V	V				
CHALLENGER	2011	PCM (Powertrain Control Module)																																														
CHALLENGER	2011	ABS (Anti Lock Brake System)	V																																													
CHALLENGER	2011	AMP (Audio)																						V	V																							
CHALLENGER	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHALLENGER	2011	DDM (Drivers Door Module)																					V																									
CHALLENGER	2011	EOM (Electric Overhead Module)																																										V				
CHALLENGER	2011	ESM (Electronic Shifter Module)																																														
CHALLENGER	2011	HFM (Hands Free Module)																																								V						
CHALLENGER	2011	HSM (Heated Seat Module)																																														
CHALLENGER	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHALLENGER	2011	ORC (Occupant Restraint Control)		V																																												
CHALLENGER	2011	PDM (Passenger Door Module)																																														
CHALLENGER	2011	RADIO (Radio)																																				V	V	V	V							
CHALLENGER	2011	SAS (Steering Angle Sensor)																																														
CHALLENGER	2011	SUNR (Sunroof Module)																																														
CHALLENGER	2011	TCM (Transmission Control Module)																																														
CHALLENGER	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHALLENGER	2011	TPM (Tire Pressure Monitor)																																														
CHALLENGER	2011	WCM(Wireless Control Modules)														V																											V	V				
CHALLENGER	2010	PCM (Powertrain Control Module)																																														
CHALLENGER	2010	ABS (Anti Lock Brake System)	V																																													
CHALLENGER	2010	AMP (Audio)																						V	V																							
CHALLENGER	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHALLENGER	2010	DDM (Drivers Door Module)																					V																									
CHALLENGER	2010	EOM (Electric Overhead Module)																																										V				
CHALLENGER	2010	ESM (Electronic Shifter Module)																																														
CHALLENGER	2010	HFM (Hands Free Module)																																								V						
CHALLENGER	2010	HSM (Heated Seat Module)																																														
CHALLENGER	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CHALLENGER	2010	ORC (Occupant Restraint Control)		V																																												
CHALLENGER	2010	PDM (Passenger Door Module)																																														
CHALLENGER	2010	RADIO (Radio)																																				V	V	V	V							
CHALLENGER	2010	SCM (Steering Column Module)																																														
CHALLENGER	2010	SUNR (Sunroof Module)																																														
CHALLENGER	2010	TCM (Transmission Control Module)																																														
CHALLENGER	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHALLENGER	2010	TPM (Tire Pressure Monitor)																																														
CHALLENGER	2010	WCM(Wireless Control Modules)														V																											V	V				
CHALLENGER	2009	PCM (Powertrain Control Module)																																														
CHALLENGER	2009	ABS (Anti Lock Brake System)	V																																													
CHALLENGER	2009	AMP (Audio)																						V	V																							
CHALLENGER	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHALLENGER	2009	DDM (Drivers Door Module)																					V																									
CHALLENGER	2009	EOM (Electric Overhead Module)																																											V			
CHALLENGER	2009	ESM (Electronic Shifter Module)																																														
CHALLENGER	2009	HFM (Hands Free Module)																																								V						
CHALLENGER	2009	HSM (Heated Seat Module)																																														
CHALLENGER	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHALLENGER	2009	ORC (Occupant Restraint Control)		V																																												
CHALLENGER	2009	PDM (Passenger Door Module)																																														
CHALLENGER	2009	RADIO (Radio)																																				V	V	V	V							
CHALLENGER	2009	SCM (Steering Column Module)																																														
CHALLENGER	2009	SUNR (Sunroof Module)																																														
CHALLENGER	2009	TCM (Transmission Control Module)																																														
CHALLENGER	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHALLENGER	2009	TPM (Tire Pressure Monitor)																																														
CHALLENGER	2009	WCM(Wireless Control Modules)														V																											V	V				
CHALLENGER	2008	PCM (Powertrain Control Module)																																														
CHALLENGER	2008	ABS (Anti Lock Brake System)	V																																													
CHALLENGER	2008	AMP (Audio)																						V	V																							
CHALLENGER	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
CHALLENGER	2008	DDM (Drivers Door Module)																					V																									
CHALLENGER	2008	EOM (Electric Overhead Module)																																											V			
CHALLENGER	2008	ESM (Electronic Shifter Module)																																														
CHALLENGER	2008	HFM (Hands Free Module)																																								V						
CHALLENGER	2008	HSM (Heated Seat Module)																																														
CHALLENGER	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
CHALLENGER	2008	ORC (Occupant Restraint Control)		V																																												
CHALLENGER	2008	PDM (Passenger Door Module)																																														
CHALLENGER	2008	RADIO (Radio)																																				V	V	V	V							
CHALLENGER	2008	SCM (Steering Column Module)																																														
CHALLENGER	2008	SUNR (Sunroof Module)																																														
CHALLENGER	2008	TCM (Transmission Control Module)																																														
CHALLENGER	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
CHALLENGER	2008	TPM (Tire Pressure Monitor)																																														
CHALLENGER	2008	WCM(Wireless Control Modules)														V																											V	V				

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND CARAVAN	2016	PCM (Powertrain Control Module)																																														
GRAND CARAVAN	2016	ABS (Anti Lock Brake System)																																														
GRAND CARAVAN	2016	AHBM (Automatic High Beam)																																														
GRAND CARAVAN	2016	AMP (Audio)																																														
GRAND CARAVAN	2016	BCM (Body Control Module)																																														
GRAND CARAVAN	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
GRAND CARAVAN	2016	CGW (Central Gateway)																																														
GRAND CARAVAN	2016	HFM (Hands Free Module)																																														
GRAND CARAVAN	2016	HVAC (Heat Vent A/C)																																														
GRAND CARAVAN	2016	IPC (Instrument Panel Cluster)																																														
GRAND CARAVAN	2016	ITM (Intrusion)																																														
GRAND CARAVAN	2016	LBSS (Left Blind Spot Sensor)																																														
GRAND CARAVAN	2016	MSMD (Memory Seet Module)																																														
GRAND CARAVAN	2016	ORC (Occupant Restraint Control)																																														
GRAND CARAVAN	2016	PTS (Park Assist Module)																																														
GRAND CARAVAN	2016	RADIO (Radio)																																														
GRAND CARAVAN	2016	RBSS (Right Blind Spot Sensor)																																														
GRAND CARAVAN	2016	RFH (Radio Frequency Hub)																																														
GRAND CARAVAN	2016	SAS (Steering Angle Sensor)																																														
GRAND CARAVAN	2016	SUNR (Sunroof Module)																																														
GRAND CARAVAN	2016	TCM (Transmission Control Module)																																														
GRAND CARAVAN	2016	TPM (Tire Pressure Monitor)																																														
GRAND CARAVAN	2016	VES3 (Vidio Entertainment System 3)																																														
GRAND CARAVAN	2016	WCM(Wireless Control Modules)																																														
GRAND CARAVAN	2015	PCM (Powertrain Control Module)																																														
GRAND CARAVAN	2015	ABS (Anti Lock Brake System)																																														
GRAND CARAVAN	2015	AHBM (Automatic High Beam)																																														
GRAND CARAVAN	2015	AMP (Audio)																																														
GRAND CARAVAN	2015	BCM (Body Control Module)																																														
GRAND CARAVAN	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
GRAND CARAVAN	2015	CGW (Central Gateway)																																														
GRAND CARAVAN	2015	HFM (Hands Free Module)																																														
GRAND CARAVAN	2015	HVAC (Heat Vent A/C)																																														
GRAND CARAVAN	2015	IPC (Instrument Panel Cluster)																																														
GRAND CARAVAN	2015	ITM (Intrusion)																																														
GRAND CARAVAN	2015	LBSS (Left Blind Spot Sensor)																																														
GRAND CARAVAN	2015	MSMD (Memory Seet Module)																																														
GRAND CARAVAN	2015	ORC (Occupant Restraint Control)																																														
GRAND CARAVAN	2015	PTS (Park Assist Module)																																														
GRAND CARAVAN	2015	RADIO (Radio)																																														
GRAND CARAVAN	2015	RBSS (Right Blind Spot Sensor)																																														
GRAND CARAVAN	2015	RFH (Radio Frequency Hub)																																														
GRAND CARAVAN	2015	SAS (Steering Angle Sensor)																																														
GRAND CARAVAN	2015	SUNR (Sunroof Module)																																														
GRAND CARAVAN	2015	TCM (Transmission Control Module)																																														
GRAND CARAVAN	2015	TPM (Tire Pressure Monitor)																																														
GRAND CARAVAN	2015	VES3 (Vidio Entertainment System 3)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND CARAVAN	2015	WCM(Wireless Control Modules)																																														
GRAND CARAVAN	2014	PCM (Powertrain Control Module)																																														
GRAND CARAVAN	2014	ABS (Anti Lock Brake System)	V																																													
GRAND CARAVAN	2014	AHBM (Automatic High Beam)																																														
GRAND CARAVAN	2014	AMP (Audio)																						V	V																							
GRAND CARAVAN	2014	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CARAVAN	2014	HFM (Hands Free Module)																																								V						
GRAND CARAVAN	2014	HSM (Heated Seat Module)																																														
GRAND CARAVAN	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CARAVAN	2014	ITM (Intrusion)																																														
GRAND CARAVAN	2014	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CARAVAN	2014	ORC (Occupant Restraint Control)		V																																												
GRAND CARAVAN	2014	PLM (Power Liftgate Module)																																														
GRAND CARAVAN	2014	PTS (Park Assist Module)																																														
GRAND CARAVAN	2014	RADIO (Radio)																																				V	V	V	V							
GRAND CARAVAN	2014	SAS (Steering Angle Sensor)																																														
GRAND CARAVAN	2014	SUNR (Sunroof Module)																																														
GRAND CARAVAN	2014	TCM (Transmission Control Module)																																														
GRAND CARAVAN	2014	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
GRAND CARAVAN	2014	TPM (Tire Pressure Monitor)																																														
GRAND CARAVAN	2014	VES3 (Vidio Entertainment System 3)																																														
GRAND CARAVAN	2014	WCM(Wireless Control Modules)														V																												V	V			
GRAND CARAVAN	2013	PCM (Powertrain Control Module)																																														
GRAND CARAVAN	2013	ABS (Anti Lock Brake System)	V																																													
GRAND CARAVAN	2013	AHBM (Automatic High Beam)																																														
GRAND CARAVAN	2013	AMP (Audio)																						V	V																							
GRAND CARAVAN	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CARAVAN	2013	HFM (Hands Free Module)																																								V						
GRAND CARAVAN	2013	HSM (Heated Seat Module)																																														
GRAND CARAVAN	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CARAVAN	2013	ITM (Intrusion)																																														
GRAND CARAVAN	2013	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CARAVAN	2013	ORC (Occupant Restraint Control)		V																																												
GRAND CARAVAN	2013	PLM (Power Liftgate Module)																																														
GRAND CARAVAN	2013	PTS (Park Assist Module)																																														
GRAND CARAVAN	2013	RADIO (Radio)																																				V	V	V	V							
GRAND CARAVAN	2013	SAS (Steering Angle Sensor)																																														
GRAND CARAVAN	2013	SUNR (Sunroof Module)																																														
GRAND CARAVAN	2013	TCM (Transmission Control Module)																																														
GRAND CARAVAN	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
GRAND CARAVAN	2013	TPM (Tire Pressure Monitor)																																														
GRAND CARAVAN	2013	VES3 (Vidio Entertainment System 3)																																														
GRAND CARAVAN	2013	WCM(Wireless Control Modules)														V																												V	V			
GRAND CARAVAN	2012	PCM (Powertrain Control Module)																																														
GRAND CARAVAN	2012	ABS (Anti Lock Brake System)	V																																													
GRAND CARAVAN	2012	AHBM (Automatic High Beam)																																														
GRAND CARAVAN	2012	AMP (Audio)																						V	V																							

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND CARAVAN	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CARAVAN	2012	HFM (Hands Free Module)																																								V						
GRAND CARAVAN	2012	HSM (Heated Seat Module)																																														
GRAND CARAVAN	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CARAVAN	2012	ITM (Intrusion)																																														
GRAND CARAVAN	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CARAVAN	2012	ORC (Occupant Restraint Control)		V																																												
GRAND CARAVAN	2012	PLM (Power Liftgate Module)																																														
GRAND CARAVAN	2012	PTS (Park Assist Module)																																														
GRAND CARAVAN	2012	RADIO (Radio)																																				V	V	V	V							
GRAND CARAVAN	2012	SAS (Steering Angle Sensor)																																														
GRAND CARAVAN	2012	SUNR (Sunroof Module)																																														
GRAND CARAVAN	2012	TCM (Transmission Control Module)																																														
GRAND CARAVAN	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND CARAVAN	2012	TPM (Tire Pressure Monitor)																																														
GRAND CARAVAN	2012	VES3 (Vidio Entertainment System 3)																																														
GRAND CARAVAN	2012	WCM(Wireless Control Modules)														V																											V	V				
GRAND CARAVAN	2011	PCM (Powertrain Control Module)																																														
GRAND CARAVAN	2011	ABS (Anti Lock Brake System)	V																																													
GRAND CARAVAN	2011	AHBM (Automatic High Beam)																																														
GRAND CARAVAN	2011	AMP (Audio)																						V	V																							
GRAND CARAVAN	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CARAVAN	2011	HFM (Hands Free Module)																																								V						
GRAND CARAVAN	2011	HSM (Heated Seat Module)																																														
GRAND CARAVAN	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CARAVAN	2011	ITM (Intrusion)																																														
GRAND CARAVAN	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CARAVAN	2011	ORC (Occupant Restraint Control)		V																																												
GRAND CARAVAN	2011	PLM (Power Liftgate Module)																																														
GRAND CARAVAN	2011	PTS (Park Assist Module)																																														
GRAND CARAVAN	2011	RADIO (Radio)																																				V	V	V	V							
GRAND CARAVAN	2011	SAS (Steering Angle Sensor)																																														
GRAND CARAVAN	2011	SUNR (Sunroof Module)																																														
GRAND CARAVAN	2011	TCM (Transmission Control Module)																																														
GRAND CARAVAN	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND CARAVAN	2011	TPM (Tire Pressure Monitor)																																														
GRAND CARAVAN	2011	VES3 (Vidio Entertainment System 3)																																														
GRAND CARAVAN	2011	WCM(Wireless Control Modules)														V																											V	V				
GRAND CARAVAN	2010	PCM (Powertrain Control Module)																																														
GRAND CARAVAN	2010	ABS (Anti Lock Brake System)	V																																													
GRAND CARAVAN	2010	AHBM (Automatic High Beam)																																														
GRAND CARAVAN	2010	AMP (Audio)																						V	V																							
GRAND CARAVAN	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CARAVAN	2010	HFM (Hands Free Module)																																								V						
GRAND CARAVAN	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CARAVAN	2010	ITM (Intrusion)																																														
GRAND CARAVAN	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND CARAVAN	2010	ORC (Occupant Restraint Control)		V																																												
GRAND CARAVAN	2010	PLM (Power Liftgate Module)																																														
GRAND CARAVAN	2010	PTS (Park Assist Module)																																														
GRAND CARAVAN	2010	RADIO (Radio)																																				V	V	V	V							
GRAND CARAVAN	2010	SAS (Steering Angle Sensor)																																														
GRAND CARAVAN	2010	SUNR (Sunroof Module)																																														
GRAND CARAVAN	2010	TCM (Transmission Control Module)																																														
GRAND CARAVAN	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND CARAVAN	2010	VES3 (Vidio Entertainment System 3)																																														
GRAND CARAVAN	2010	WCM(Wireless Control Modules)														V																											V	V				
GRAND CARAVAN	2009	PCM (Powertrain Control Module)																																														
GRAND CARAVAN	2009	ABS (Anti Lock Brake System)	V																																													
GRAND CARAVAN	2009	AHBM (Automatic High Beam)																																														
GRAND CARAVAN	2009	AMP (Audio)																						V	V																							
GRAND CARAVAN	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CARAVAN	2009	HFM (Hands Free Module)																																								V						
GRAND CARAVAN	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CARAVAN	2009	ITM (Intrusion)																																														
GRAND CARAVAN	2009	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CARAVAN	2009	ORC (Occupant Restraint Control)		V																																												
GRAND CARAVAN	2009	PLM (Power Liftgate Module)																																														
GRAND CARAVAN	2009	PTS (Park Assist Module)																																														
GRAND CARAVAN	2009	RADIO (Radio)																																				V	V	V	V							
GRAND CARAVAN	2009	SAS (Steering Angle Sensor)																																														
GRAND CARAVAN	2009	SUNR (Sunroof Module)																																														
GRAND CARAVAN	2009	TCM (Transmission Control Module)																																														
GRAND CARAVAN	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND CARAVAN	2009	VES3 (Vidio Entertainment System 3)																																														
GRAND CARAVAN	2009	WCM(Wireless Control Modules)														V																											V	V				
GRAND CARAVAN	2008	PCM (Powertrain Control Module)																																														
GRAND CARAVAN	2008	ABS (Anti Lock Brake System)	V																																													
GRAND CARAVAN	2008	AHBM (Automatic High Beam)																																														
GRAND CARAVAN	2008	AMP (Audio)																						V	V																							
GRAND CARAVAN	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CARAVAN	2008	HFM (Hands Free Module)																																								V						
GRAND CARAVAN	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CARAVAN	2008	ITM (Intrusion)																																														
GRAND CARAVAN	2008	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CARAVAN	2008	ORC (Occupant Restraint Control)		V																																												
GRAND CARAVAN	2008	PLM (Power Liftgate Module)																																														
GRAND CARAVAN	2008	PTS (Park Assist Module)																																														
GRAND CARAVAN	2008	RADIO (Radio)																																				V	V	V	V							
GRAND CARAVAN	2008	SAS (Steering Angle Sensor)																																														
GRAND CARAVAN	2008	SUNR (Sunroof Module)																																														
GRAND CARAVAN	2008	TCM (Transmission Control Module)																																														
GRAND CARAVAN	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND CARAVAN	2008	VES3 (Vidio Entertainment System 3)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND CARAVAN	2008	WCM(Wireless Control Modules)														V																												V	V			
DODGE RAM	2010	PCM (Powertrain Control Module)																																														
DODGE RAM	2010	ABS (Anti Lock Brake System)	V																																													
DODGE RAM	2010	AMP (Audio)																						V	V																							
DODGE RAM	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DODGE RAM	2010	EOM (Electric Overhead Module)																																										V				
DODGE RAM	2010	HFM (Hands Free Module)																																								V						
DODGE RAM	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
DODGE RAM	2010	ORC (Occupant Restraint Control)		V																																												
DODGE RAM	2010	RADIO (Radio)																																				V	V	V	V							
DODGE RAM	2010	SAS (Steering Angle Sensor)																																														
DODGE RAM	2010	SDAR (Satellite Radio)																																														
DODGE RAM	2010	SUNR (Sunroof Module)																																														
DODGE RAM	2010	TCM (Transmission Control Module)																																														
DODGE RAM	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
DODGE RAM	2010	WCM(Wireless Control Modules)														V																												V	V			
DODGE RAM	2009	PCM (Powertrain Control Module)																																														
DODGE RAM	2009	ABS (Anti Lock Brake System)	V																																													
DODGE RAM	2009	AMP (Audio)																						V	V																							
DODGE RAM	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DODGE RAM	2009	EOM (Electric Overhead Module)																																										V				
DODGE RAM	2009	HFM (Hands Free Module)																																								V						
DODGE RAM	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
DODGE RAM	2009	ORC (Occupant Restraint Control)		V																																												
DODGE RAM	2009	RADIO (Radio)																																				V	V	V	V							
DODGE RAM	2009	SAS (Steering Angle Sensor)																																														
DODGE RAM	2009	SDAR (Satellite Radio)																																														
DODGE RAM	2009	SUNR (Sunroof Module)																																														
DODGE RAM	2009	TCM (Transmission Control Module)																																														
DODGE RAM	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
DODGE RAM	2009	WCM(Wireless Control Modules)														V																												V	V			
DODGE RAM	2008	PCM (Powertrain Control Module)																																														
DODGE RAM	2008	ABS (Anti Lock Brake System)	V																																													
DODGE RAM	2008	AMP (Audio)																						V	V																							
DODGE RAM	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DODGE RAM	2008	EOM (Electric Overhead Module)																																										V				
DODGE RAM	2008	HFM (Hands Free Module)																																								V						
DODGE RAM	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
DODGE RAM	2008	ORC (Occupant Restraint Control)		V																																												
DODGE RAM	2008	RADIO (Radio)																																				V	V	V	V							
DODGE RAM	2008	SAS (Steering Angle Sensor)																																														
DODGE RAM	2008	SDAR (Satellite Radio)																																														
DODGE RAM	2008	SUNR (Sunroof Module)																																														
DODGE RAM	2008	TCM (Transmission Control Module)																																														
DODGE RAM	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
DODGE RAM	2008	WCM(Wireless Control Modules)														V																												V	V			
DODGE RAM	2007	PCM (Powertrain Control Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
DODGE RAM	2007	ABS (Anti Lock Brake System)	V																																													
DODGE RAM	2007	AMP (Audio)																						V	V																							
DODGE RAM	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DODGE RAM	2007	EOM (Electric Overhead Module)																																										V			
DODGE RAM	2007	HFM (Hands Free Module)																																							V						
DODGE RAM	2007	HVAC (Heat Vent A/C)																								V	V	V	V																		
DODGE RAM	2007	ORC (Occupant Restraint Control)		V																																											
DODGE RAM	2007	RADIO (Radio)																																				V	V	V	V						
DODGE RAM	2007	SAS (Steering Angle Sensor)																																													
DODGE RAM	2007	SDAR (Satellite Radio)																																													
DODGE RAM	2007	SUNR (Sunroof Module)																																													
DODGE RAM	2007	TCM (Transmission Control Module)																																													
DODGE RAM	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
DODGE RAM	2007	WCM(Wireless Control Modules)														V																											V	V			
DODGE RAM	2006	PCM (Powertrain Control Module)																																													
DODGE RAM	2006	ABS (Anti Lock Brake System)	V																																												
DODGE RAM	2006	AMP (Audio)																						V	V																							
DODGE RAM	2006	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
DODGE RAM	2006	EOM (Electric Overhead Module)																																										V			
DODGE RAM	2006	HFM (Hands Free Module)																																							V						
DODGE RAM	2006	HVAC (Heat Vent A/C)																								V	V	V	V																		
DODGE RAM	2006	OCM (Occupant Classification Module)																																													
DODGE RAM	2006	ORC (Occupant Restraint Control)		V																																											
DODGE RAM	2006	RADIO (Radio)																																				V	V	V	V						
DODGE RAM	2006	SDAR (Satellite Radio)																																													
DODGE RAM	2006	SUNR (Sunroof Module)																																													
DODGE RAM	2006	TCM (Transmission Control Module)																																													
DODGE RAM	2006	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
DODGE RAM	2006	WCM(Wireless Control Modules)														V																											V	V			
RAM 1500	2016	PCM (Powertrain Control Module)																																													
RAM 1500	2016	ABS (Anti Lock Brake System)																																													
RAM 1500	2016	AMP (Audio)																																													
RAM 1500	2016	BCM (Body Control Module)																																													
RAM 1500	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																													
RAM 1500	2016	CGW (Central Gateway)																																													
RAM 1500	2016	DDM (Drivers Door Module)																																													
RAM 1500	2016	DTCM (Drive Train Control Module)																																													
RAM 1500	2016	EDM (Electronic Damper Module)																																													
RAM 1500	2016	EPS (Electric Power Steering)																																													
RAM 1500	2016	ESM (Electronic Shifter Module)																																													
RAM 1500	2016	HSM (Heated Seat Module)																																													
RAM 1500	2016	HVAC (Heat Vent A/C)																																													
RAM 1500	2016	ICS (Integrated Center Stack)																																													
RAM 1500	2016	IPC (Instrument Panel Cluster)																																													
RAM 1500	2016	MSMD (Memory Seet Module)																																													
RAM 1500	2016	ORC (Occupant Restraint Control)																																													
RAM 1500	2016	PDM (Passenger Door Module)																																													

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 1500	2016	PTS (Park Assist Module)																																														
RAM 1500	2016	RADIO (Radio)																																														
RAM 1500	2016	RFH (Radio Frequency Hub)																																														
RAM 1500	2016	SCM (Steering Column Module)																																														
RAM 1500	2016	TCM (Transmission Control Module)																																														
RAM 1500	2016	WCM(Wireless Control Modules)																																														
RAM 1500	2015	PCM (Powertrain Control Module)																																														
RAM 1500	2015	ABS (Anti Lock Brake System)																																														
RAM 1500	2015	AMP (Audio)																																														
RAM 1500	2015	BCM (Body Control Module)																																														
RAM 1500	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RAM 1500	2015	CGW (Central Gateway)																																														
RAM 1500	2015	DDM (Drivers Door Module)																																														
RAM 1500	2015	DTCM (Drive Train Control Module)																																														
RAM 1500	2015	EDM (Electronic Damper Module)																																														
RAM 1500	2015	EPS (Electric Power Steering)																																														
RAM 1500	2015	ESM (Electronic Shifter Module)																																														
RAM 1500	2015	HSM (Heated Seat Module)																																														
RAM 1500	2015	HVAC (Heat Vent A/C)																																														
RAM 1500	2015	ICS (Integrated Center Stack)																																														
RAM 1500	2015	IPC (Instrument Panel Cluster)																																														
RAM 1500	2015	MSMD (Memory Seet Module)																																														
RAM 1500	2015	ORC (Occupant Restraint Control)																																														
RAM 1500	2015	PDM (Passenger Door Module)																																														
RAM 1500	2015	PTS (Park Assist Module)																																														
RAM 1500	2015	RADIO (Radio)																																														
RAM 1500	2015	RFH (Radio Frequency Hub)																																														
RAM 1500	2015	SCM (Steering Column Module)																																														
RAM 1500	2015	TCM (Transmission Control Module)																																														
RAM 1500	2015	WCM(Wireless Control Modules)																																														
RAM 1500	2014	PCM (Powertrain Control Module)																																														
RAM 1500	2014	ABS (Anti Lock Brake System)	V																																													
RAM 1500	2014	AMP (Audio)																						V	V																							
RAM 1500	2014	DDM (Drivers Door Module)																					V																									
RAM 1500	2014	DTCM (Drive Train Control Module)																																														
RAM 1500	2014	ESM (Electronic Shifter Module)																																														
RAM 1500	2014	HSM (Heated Seat Module)																																														
RAM 1500	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 1500	2014	ORC (Occupant Restraint Control)		V																																												
RAM 1500	2014	PDM (Passenger Door Module)																																														
RAM 1500	2014	PTS (Park Assist Module)																																														
RAM 1500	2014	RADIO (Radio)																																				V	V	V	V							
RAM 1500	2014	TCM (Transmission Control Module)																																														
RAM 1500	2013	PCM (Powertrain Control Module)																																														
RAM 1500	2013	ABS (Anti Lock Brake System)	V																																													
RAM 1500	2013	AMP (Audio)																						V	V																							
RAM 1500	2013	DDM (Drivers Door Module)																					V																									

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 1500	2013	DTCM (Drive Train Control Module)																																														
RAM 1500	2013	ESM (Electronic Shifter Module)																																														
RAM 1500	2013	HSM (Heated Seat Module)																																														
RAM 1500	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 1500	2013	ORC (Occupant Restraint Control)		V																																												
RAM 1500	2013	PDM (Passenger Door Module)																																														
RAM 1500	2013	PTS (Park Assist Module)																																														
RAM 1500	2013	RADIO (Radio)																																				V	V	V	V							
RAM 1500	2013	TCM (Transmission Control Module)																																														
RAM 1500	2013	TPM (Tire Pressure Monitor)																																														
RAM 1500	2012	PCM (Powertrain Control Module)																																														
RAM 1500	2012	ABS (Anti Lock Brake System)	V																																													
RAM 1500	2012	AMP (Audio)																						V	V																							
RAM 1500	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 1500	2012	DTCM (Drive Train Control Module)																																														
RAM 1500	2012	HFM (Hands Free Module)																																								V						
RAM 1500	2012	HSM (Heated Seat Module)																																														
RAM 1500	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 1500	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 1500	2012	ORC (Occupant Restraint Control)		V																																												
RAM 1500	2012	PTS (Park Assist Module)																																														
RAM 1500	2012	RADIO (Radio)																																				V	V	V	V							
RAM 1500	2012	SAS (Steering Angle Sensor)																																														
RAM 1500	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
RAM 1500	2012	TPM (Tire Pressure Monitor)																																														
RAM 1500	2012	VES3 (Vidio Entertainment System 3)																																														
RAM 1500	2012	WCM(Wireless Control Modules)														V																											V	V				
RAM 1500	2011	PCM (Powertrain Control Module)																																														
RAM 1500	2011	ABS (Anti Lock Brake System)	V																																													
RAM 1500	2011	AMP (Audio)																						V	V																							
RAM 1500	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 1500	2011	DTCM (Drive Train Control Module)																																														
RAM 1500	2011	HFM (Hands Free Module)																																								V						
RAM 1500	2011	HSM (Heated Seat Module)																																														
RAM 1500	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 1500	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 1500	2011	ORC (Occupant Restraint Control)		V																																												
RAM 1500	2011	PTS (Park Assist Module)																																														
RAM 1500	2011	RADIO (Radio)																																				V	V	V	V							
RAM 1500	2011	SAS (Steering Angle Sensor)																																														
RAM 1500	2011	TCM (Transmission Control Module)																																														
RAM 1500	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
RAM 1500	2011	TPM (Tire Pressure Monitor)																																														
RAM 1500	2011	VES3 (Vidio Entertainment System 3)																																														
RAM 1500	2011	WCM(Wireless Control Modules)														V																											V	V				
RAM 1500	2010	PCM (Powertrain Control Module)																																														
RAM 1500	2010	ABS (Anti Lock Brake System)	V																																													

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 1500	2010	AMP (Audio)																						V	V																							
RAM 1500	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 1500	2010	DTCM (Drive Train Control Module)																																														
RAM 1500	2010	HFM (Hands Free Module)																																								V						
RAM 1500	2010	HSM (Heated Seat Module)																																														
RAM 1500	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 1500	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 1500	2010	ORC (Occupant Restraint Control)		V																																												
RAM 1500	2010	PTS (Park Assist Module)																																														
RAM 1500	2010	RADIO (Radio)																																				V	V	V	V							
RAM 1500	2010	SAS (Steering Angle Sensor)																																														
RAM 1500	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
RAM 1500	2010	TPM (Tire Pressure Monitor)																																														
RAM 1500	2010	VES3 (Vidio Entertainment System 3)																																														
RAM 1500	2010	WCM(Wireless Control Modules)														V																											V	V				
RAM 1500	2009	PCM (Powertrain Control Module)																																														
RAM 1500	2009	ABS (Anti Lock Brake System)	V																																													
RAM 1500	2009	AMP (Audio)																						V	V																							
RAM 1500	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 1500	2009	DTCM (Drive Train Control Module)																																														
RAM 1500	2009	HFM (Hands Free Module)																																								V						
RAM 1500	2009	HSM (Heated Seat Module)																																														
RAM 1500	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 1500	2009	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 1500	2009	ORC (Occupant Restraint Control)		V																																												
RAM 1500	2009	PTS (Park Assist Module)																																														
RAM 1500	2009	RADIO (Radio)																																				V	V	V	V							
RAM 1500	2009	SAS (Steering Angle Sensor)																																														
RAM 1500	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
RAM 1500	2009	VES3 (Vidio Entertainment System 3)																																														
RAM 1500	2009	WCM(Wireless Control Modules)														V																											V	V				
RAM 2500	2016	PCM (Powertrain Control Module)																																														
RAM 2500	2016	ABS (Anti Lock Brake System)																																														
RAM 2500	2016	AMP (Audio)																																														
RAM 2500	2016	BCM (Body Control Module)																																														
RAM 2500	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RAM 2500	2016	CGW (Central Gateway)																																														
RAM 2500	2016	DDM (Drivers Door Module)																																														
RAM 2500	2016	DTCM (Drive Train Control Module)																																														
RAM 2500	2016	EDM (Electronic Damper Module)																																														
RAM 2500	2016	EPS (Electric Power Steering)																																														
RAM 2500	2016	ESM (Electronic Shifter Module)																																														
RAM 2500	2016	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
RAM 2500	2016	HSM (Heated Seat Module)																																														
RAM 2500	2016	HVAC (Heat Vent A/C)																																														
RAM 2500	2016	ICS (Integrated Center Stack)																																														
RAM 2500	2016	IPC (Instrument Panel Cluster)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 2500	2016	MSMD (Memory Seet Module)																																														
RAM 2500	2016	ORC (Occupant Restraint Control)																																														
RAM 2500	2016	PDM (Passenger Door Module)																																														
RAM 2500	2016	PTS (Park Assist Module)																																														
RAM 2500	2016	RADIO (Radio)																																														
RAM 2500	2016	RFH (Radio Frequency Hub)																																														
RAM 2500	2016	SCM (Steering Column Module)																																														
RAM 2500	2016	TCM (Transmission Control Module)																																														
RAM 2500	2016	WCM(Wireless Control Modules)																																														
RAM 2500	2015	PCM (Powertrain Control Module)																																														
RAM 2500	2015	ABS (Anti Lock Brake System)																																														
RAM 2500	2015	AMP (Audio)																																														
RAM 2500	2015	BCM (Body Control Module)																																														
RAM 2500	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RAM 2500	2015	CGW (Central Gateway)																																														
RAM 2500	2015	DDM (Drivers Door Module)																																														
RAM 2500	2015	DTCM (Drive Train Control Module)																																														
RAM 2500	2015	EDM (Electronic Damper Module)																																														
RAM 2500	2015	EPS (Electric Power Steering)																																														
RAM 2500	2015	ESM (Electronic Shifter Module)																																														
RAM 2500	2015	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
RAM 2500	2015	HSM (Heated Seat Module)																																														
RAM 2500	2015	HVAC (Heat Vent A/C)																																														
RAM 2500	2015	ICS (Integrated Center Stack)																																														
RAM 2500	2015	IPC (Instrument Panel Cluster)																																														
RAM 2500	2015	MSMD (Memory Seet Module)																																														
RAM 2500	2015	ORC (Occupant Restraint Control)																																														
RAM 2500	2015	PDM (Passenger Door Module)																																														
RAM 2500	2015	PTS (Park Assist Module)																																														
RAM 2500	2015	RADIO (Radio)																																														
RAM 2500	2015	RFH (Radio Frequency Hub)																																														
RAM 2500	2015	SCM (Steering Column Module)																																														
RAM 2500	2015	TCM (Transmission Control Module)																																														
RAM 2500	2015	WCM(Wireless Control Modules)																																														
RAM 2500	2014	PCM (Powertrain Control Module)																																														
RAM 2500	2014	ABS (Anti Lock Brake System)	V																																													
RAM 2500	2014	AMP (Audio)																						V	V																							
RAM 2500	2014	DDM (Drivers Door Module)																					V																									
RAM 2500	2014	DTCM (Drive Train Control Module)																																														
RAM 2500	2014	HSM (Heated Seat Module)																																														
RAM 2500	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 2500	2014	ORC (Occupant Restraint Control)		V																																												
RAM 2500	2014	PDM (Passenger Door Module)																																														
RAM 2500	2014	PTS (Park Assist Module)																																														
RAM 2500	2014	RADIO (Radio)																																				V	V	V	V							
RAM 2500	2014	TCM (Transmission Control Module)																																														
RAM 2500	2013	PCM (Powertrain Control Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 2500	2013	ABS (Anti Lock Brake System)	V																																													
RAM 2500	2013	AMP (Audio)																						V	V																							
RAM 2500	2013	DDM (Drivers Door Module)																					V																									
RAM 2500	2013	DTCM (Drive Train Control Module)																																														
RAM 2500	2013	HSM (Heated Seat Module)																																														
RAM 2500	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 2500	2013	ORC (Occupant Restraint Control)		V																																												
RAM 2500	2013	PDM (Passenger Door Module)																																														
RAM 2500	2013	PTS (Park Assist Module)																																														
RAM 2500	2013	RADIO (Radio)																																				V	V	V	V							
RAM 2500	2013	TCM (Transmission Control Module)																																														
RAM 2500	2013	TPM (Tire Pressure Monitor)																																														
RAM 2500	2012	PCM (Powertrain Control Module)																																														
RAM 2500	2012	ABS (Anti Lock Brake System)	V																																													
RAM 2500	2012	AMP (Audio)																						V	V																							
RAM 2500	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 2500	2012	DTCM (Drive Train Control Module)																																														
RAM 2500	2012	HFM (Hands Free Module)																																								V						
RAM 2500	2012	HSM (Heated Seat Module)																																														
RAM 2500	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 2500	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 2500	2012	ORC (Occupant Restraint Control)		V																																												
RAM 2500	2012	PTS (Park Assist Module)																																														
RAM 2500	2012	RADIO (Radio)																																				V	V	V	V							
RAM 2500	2012	SAS (Steering Angle Sensor)																																														
RAM 2500	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
RAM 2500	2012	TPM (Tire Pressure Monitor)																																														
RAM 2500	2012	VES3 (Vidio Entertainment System 3)																																														
RAM 2500	2012	WCM(Wireless Control Modules)														V																											V	V				
RAM 2500	2011	PCM (Powertrain Control Module)																																														
RAM 2500	2011	ABS (Anti Lock Brake System)	V																																													
RAM 2500	2011	AMP (Audio)																						V	V																							
RAM 2500	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 2500	2011	DTCM (Drive Train Control Module)																																														
RAM 2500	2011	HFM (Hands Free Module)																																								V						
RAM 2500	2011	HSM (Heated Seat Module)																																														
RAM 2500	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 2500	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 2500	2011	ORC (Occupant Restraint Control)		V																																												
RAM 2500	2011	PTS (Park Assist Module)																																														
RAM 2500	2011	RADIO (Radio)																																				V	V	V	V							
RAM 2500	2011	SAS (Steering Angle Sensor)																																														
RAM 2500	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
RAM 2500	2011	TPM (Tire Pressure Monitor)																																														
RAM 2500	2011	VES3 (Vidio Entertainment System 3)																																														
RAM 2500	2011	WCM(Wireless Control Modules)														V																											V	V				
RAM 2500	2010	PCM (Powertrain Control Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 2500	2010	ABS (Anti Lock Brake System)	V																																													
RAM 2500	2010	AMP (Audio)																						V	V																							
RAM 2500	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 2500	2010	DTCM (Drive Train Control Module)																																														
RAM 2500	2010	HFM (Hands Free Module)																																								V						
RAM 2500	2010	HSM (Heated Seat Module)																																														
RAM 2500	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 2500	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 2500	2010	ORC (Occupant Restraint Control)		V																																												
RAM 2500	2010	PTS (Park Assist Module)																																														
RAM 2500	2010	RADIO (Radio)																																				V	V	V	V							
RAM 2500	2010	SAS (Steering Angle Sensor)																																														
RAM 2500	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
RAM 2500	2010	TPM (Tire Pressure Monitor)																																														
RAM 2500	2010	VES3 (Vidio Entertainment System 3)																																														
RAM 2500	2010	WCM(Wireless Control Modules)														V																											V	V				
RAM 3500 PICKUP	2016	PCM (Powertrain Control Module)																																														
RAM 3500 PICKUP	2016	ABS (Anti Lock Brake System)																																														
RAM 3500 PICKUP	2016	AMP (Audio)																																														
RAM 3500 PICKUP	2016	BCM (Body Control Module)																																														
RAM 3500 PICKUP	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RAM 3500 PICKUP	2016	CGW (Central Gateway)																																														
RAM 3500 PICKUP	2016	DDM (Drivers Door Module)																																														
RAM 3500 PICKUP	2016	DTCM (Drive Train Control Module)																																														
RAM 3500 PICKUP	2016	EDM (Electronic Damper Module)																																														
RAM 3500 PICKUP	2016	EPS (Electric Power Steering)																																														
RAM 3500 PICKUP	2016	ESM (Electronic Shifter Module)																																														
RAM 3500 PICKUP	2016	HSM (Heated Seat Module)																																														
RAM 3500 PICKUP	2016	HVAC (Heat Vent A/C)																																														
RAM 3500 PICKUP	2016	ICS (Integrated Center Stack)																																														
RAM 3500 PICKUP	2016	IPC (Instrument Panel Cluster)																																														
RAM 3500 PICKUP	2016	MSMD (Memory Seet Module)																																														
RAM 3500 PICKUP	2016	ORC (Occupant Restraint Control)																																														
RAM 3500 PICKUP	2016	PDM (Passenger Door Module)																																														
RAM 3500 PICKUP	2016	PTS (Park Assist Module)																																														
RAM 3500 PICKUP	2016	RADIO (Radio)																																														
RAM 3500 PICKUP	2016	RFH (Radio Frequency Hub)																																														
RAM 3500 PICKUP	2016	SCM (Steering Column Module)																																														
RAM 3500 PICKUP	2016	TCM (Transmission Control Module)																																														
RAM 3500 PICKUP	2016	WCM(Wireless Control Modules)																																														
RAM 3500 PICKUP	2015	PCM (Powertrain Control Module)																																														
RAM 3500 PICKUP	2015	ABS (Anti Lock Brake System)																																														
RAM 3500 PICKUP	2015	AMP (Audio)																																														
RAM 3500 PICKUP	2015	BCM (Body Control Module)																																														
RAM 3500 PICKUP	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RAM 3500 PICKUP	2015	CGW (Central Gateway)																																														
RAM 3500 PICKUP	2015	DDM (Drivers Door Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 3500 PICKUP	2015	DTCM (Drive Train Control Module)																																														
RAM 3500 PICKUP	2015	EDM (Electronic Damper Module)																																														
RAM 3500 PICKUP	2015	EPS (Electric Power Steering)																																														
RAM 3500 PICKUP	2015	ESM (Electronic Shifter Module)																																														
RAM 3500 PICKUP	2015	HSM (Heated Seat Module)																																														
RAM 3500 PICKUP	2015	HVAC (Heat Vent A/C)																																														
RAM 3500 PICKUP	2015	ICS (Integrated Center Stack)																																														
RAM 3500 PICKUP	2015	IPC (Instrument Panel Cluster)																																														
RAM 3500 PICKUP	2015	MSMD (Memory Seet Module)																																														
RAM 3500 PICKUP	2015	ORC (Occupant Restraint Control)																																														
RAM 3500 PICKUP	2015	PDM (Passenger Door Module)																																														
RAM 3500 PICKUP	2015	PTS (Park Assist Module)																																														
RAM 3500 PICKUP	2015	RADIO (Radio)																																														
RAM 3500 PICKUP	2015	RFH (Radio Frequency Hub)																																														
RAM 3500 PICKUP	2015	SCM (Steering Column Module)																																														
RAM 3500 PICKUP	2015	TCM (Transmission Control Module)																																														
RAM 3500 PICKUP	2015	WCM(Wireless Control Modules)																																														
RAM 3500 PICKUP	2014	PCM (Powertrain Control Module)																																														
RAM 3500 PICKUP	2014	ABS (Anti Lock Brake System)	V																																													
RAM 3500 PICKUP	2014	AMP (Audio)																						V	V																							
RAM 3500 PICKUP	2014	DDM (Drivers Door Module)																					V																									
RAM 3500 PICKUP	2014	DTCM (Drive Train Control Module)																																														
RAM 3500 PICKUP	2014	HSM (Heated Seat Module)																																														
RAM 3500 PICKUP	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 3500 PICKUP	2014	ORC (Occupant Restraint Control)		V																																												
RAM 3500 PICKUP	2014	PDM (Passenger Door Module)																																														
RAM 3500 PICKUP	2014	PTS (Park Assist Module)																																														
RAM 3500 PICKUP	2014	RADIO (Radio)																																					V	V	V	V						
RAM 3500 PICKUP	2014	TCM (Transmission Control Module)																																														
RAM 3500 PICKUP	2013	PCM (Powertrain Control Module)																																														
RAM 3500 PICKUP	2013	ABS (Anti Lock Brake System)	V																																													
RAM 3500 PICKUP	2013	AMP (Audio)																						V	V																							
RAM 3500 PICKUP	2013	DDM (Drivers Door Module)																					V																									
RAM 3500 PICKUP	2013	DTCM (Drive Train Control Module)																																														
RAM 3500 PICKUP	2013	HSM (Heated Seat Module)																																														
RAM 3500 PICKUP	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 3500 PICKUP	2013	ORC (Occupant Restraint Control)		V																																												
RAM 3500 PICKUP	2013	PDM (Passenger Door Module)																																														
RAM 3500 PICKUP	2013	PTS (Park Assist Module)																																														
RAM 3500 PICKUP	2013	RADIO (Radio)																																					V	V	V	V						
RAM 3500 PICKUP	2013	TCM (Transmission Control Module)																																														
RAM 3500 PICKUP	2012	PCM (Powertrain Control Module)																																														
RAM 3500 PICKUP	2012	ABS (Anti Lock Brake System)	V																																													
RAM 3500 PICKUP	2012	AMP (Audio)																						V	V																							
RAM 3500 PICKUP	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 3500 PICKUP	2012	DTCM (Drive Train Control Module)																																														
RAM 3500 PICKUP	2012	HFM (Hands Free Module)																																								V						

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 3500 PICKUP	2012	HSM (Heated Seat Module)																																														
RAM 3500 PICKUP	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 3500 PICKUP	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 3500 PICKUP	2012	ORC (Occupant Restraint Control)		V																																												
RAM 3500 PICKUP	2012	PTS (Park Assist Module)																																														
RAM 3500 PICKUP	2012	RADIO (Radio)																																				V	V	V	V							
RAM 3500 PICKUP	2012	SAS (Steering Angle Sensor)																																														
RAM 3500 PICKUP	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
RAM 3500 PICKUP	2012	VES3 (Vidio Entertainment System 3)																																														
RAM 3500 PICKUP	2012	WCM(Wireless Control Modules)														V																											V	V				
RAM 3500 PICKUP	2011	PCM (Powertrain Control Module)																																														
RAM 3500 PICKUP	2011	ABS (Anti Lock Brake System)	V																																													
RAM 3500 PICKUP	2011	AMP (Audio)																						V	V																							
RAM 3500 PICKUP	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 3500 PICKUP	2011	DTCM (Drive Train Control Module)																																														
RAM 3500 PICKUP	2011	HFM (Hands Free Module)																																								V						
RAM 3500 PICKUP	2011	HSM (Heated Seat Module)																																														
RAM 3500 PICKUP	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 3500 PICKUP	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 3500 PICKUP	2011	ORC (Occupant Restraint Control)		V																																												
RAM 3500 PICKUP	2011	PTS (Park Assist Module)																																														
RAM 3500 PICKUP	2011	RADIO (Radio)																																				V	V	V	V							
RAM 3500 PICKUP	2011	SAS (Steering Angle Sensor)																																														
RAM 3500 PICKUP	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
RAM 3500 PICKUP	2011	VES3 (Vidio Entertainment System 3)																																														
RAM 3500 PICKUP	2011	WCM(Wireless Control Modules)														V																											V	V				
RAM 3500 PICKUP	2010	PCM (Powertrain Control Module)																																														
RAM 3500 PICKUP	2010	ABS (Anti Lock Brake System)	V																																													
RAM 3500 PICKUP	2010	AMP (Audio)																						V	V																							
RAM 3500 PICKUP	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 3500 PICKUP	2010	DTCM (Drive Train Control Module)																																														
RAM 3500 PICKUP	2010	HFM (Hands Free Module)																																								V						
RAM 3500 PICKUP	2010	HSM (Heated Seat Module)																																														
RAM 3500 PICKUP	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 3500 PICKUP	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 3500 PICKUP	2010	ORC (Occupant Restraint Control)		V																																												
RAM 3500 PICKUP	2010	PTS (Park Assist Module)																																														
RAM 3500 PICKUP	2010	RADIO (Radio)																																				V	V	V	V							
RAM 3500 PICKUP	2010	SAS (Steering Angle Sensor)																																														
RAM 3500 PICKUP	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
RAM 3500 PICKUP	2010	VES3 (Vidio Entertainment System 3)																																														
RAM 3500 PICKUP	2010	WCM(Wireless Control Modules)														V																											V	V				
RAM 3500 Cab Chassis	2016	PCM (Powertrain Control Module)																																														
RAM 3500 Cab Chassis	2016	ABS (Anti Lock Brake System)																																														
RAM 3500 Cab Chassis	2016	AMP (Audio)																																														
RAM 3500 Cab Chassis	2016	BCM (Body Control Module)																																														
RAM 3500 Cab Chassis	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 3500 Cab Chassis	2016	CGW (Central Gateway)																																														
RAM 3500 Cab Chassis	2016	DDM (Drivers Door Module)																																														
RAM 3500 Cab Chassis	2016	DTCM (Drive Train Control Module)																																														
RAM 3500 Cab Chassis	2016	EDM (Electronic Damper Module)																																														
RAM 3500 Cab Chassis	2016	EPS (Electric Power Steering)																																														
RAM 3500 Cab Chassis	2016	ESM (Electronic Shifter Module)																																														
RAM 3500 Cab Chassis	2016	HSM (Heated Seat Module)																																														
RAM 3500 Cab Chassis	2016	HVAC (Heat Vent A/C)																																														
RAM 3500 Cab Chassis	2016	ICS (Integrated Center Stack)																																														
RAM 3500 Cab Chassis	2016	IPC (Instrument Panel Cluster)																																														
RAM 3500 Cab Chassis	2016	MSMD (Memory Seet Module)																																														
RAM 3500 Cab Chassis	2016	ORC (Occupant Restraint Control)																																														
RAM 3500 Cab Chassis	2016	PDM (Passenger Door Module)																																														
RAM 3500 Cab Chassis	2016	PTS (Park Assist Module)																																														
RAM 3500 Cab Chassis	2016	RADIO (Radio)																																														
RAM 3500 Cab Chassis	2016	RFH (Radio Frequency Hub)																																														
RAM 3500 Cab Chassis	2016	SCM (Steering Column Module)																																														
RAM 3500 Cab Chassis	2016	TCM (Transmission Control Module)																																														
RAM 3500 Cab Chassis	2016	WCM(Wireless Control Modules)																																														
RAM 3500 Cab Chassis	2015	PCM (Powertrain Control Module)																																														
RAM 3500 Cab Chassis	2015	ABS (Anti Lock Brake System)																																														
RAM 3500 Cab Chassis	2015	AMP (Audio)																																														
RAM 3500 Cab Chassis	2015	BCM (Body Control Module)																																														
RAM 3500 Cab Chassis	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RAM 3500 Cab Chassis	2015	CGW (Central Gateway)																																														
RAM 3500 Cab Chassis	2015	DDM (Drivers Door Module)																																														
RAM 3500 Cab Chassis	2015	DTCM (Drive Train Control Module)																																														
RAM 3500 Cab Chassis	2015	EDM (Electronic Damper Module)																																														
RAM 3500 Cab Chassis	2015	EPS (Electric Power Steering)																																														
RAM 3500 Cab Chassis	2015	ESM (Electronic Shifter Module)																																														
RAM 3500 Cab Chassis	2015	HSM (Heated Seat Module)																																														
RAM 3500 Cab Chassis	2015	HVAC (Heat Vent A/C)																																														
RAM 3500 Cab Chassis	2015	ICS (Integrated Center Stack)																																														
RAM 3500 Cab Chassis	2015	IPC (Instrument Panel Cluster)																																														
RAM 3500 Cab Chassis	2015	MSMD (Memory Seet Module)																																														
RAM 3500 Cab Chassis	2015	ORC (Occupant Restraint Control)																																														
RAM 3500 Cab Chassis	2015	PDM (Passenger Door Module)																																														
RAM 3500 Cab Chassis	2015	PTS (Park Assist Module)																																														
RAM 3500 Cab Chassis	2015	RADIO (Radio)																																														
RAM 3500 Cab Chassis	2015	RFH (Radio Frequency Hub)																																														
RAM 3500 Cab Chassis	2015	SCM (Steering Column Module)																																														
RAM 3500 Cab Chassis	2015	TCM (Transmission Control Module)																																														
RAM 3500 Cab Chassis	2015	WCM(Wireless Control Modules)																																														
RAM 3500 Cab Chassis	2014	PCM (Powertrain Control Module)																																														
RAM 3500 Cab Chassis	2014	ABS (Anti Lock Brake System)	V																																													
RAM 3500 Cab Chassis	2014	AMP (Audio)																						V	V																							
RAM 3500 Cab Chassis	2014	DDM (Drivers Door Module)																					V																									

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 3500 Cab Chassis	2014	DTCM (Drive Train Control Module)																																														
RAM 3500 Cab Chassis	2014	HSM (Heated Seat Module)																																														
RAM 3500 Cab Chassis	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 3500 Cab Chassis	2014	ORC (Occupant Restraint Control)		V																																												
RAM 3500 Cab Chassis	2014	PDM (Passenger Door Module)																																														
RAM 3500 Cab Chassis	2014	PTS (Park Assist Module)																																														
RAM 3500 Cab Chassis	2014	RADIO (Radio)																																				V	V	V	V							
RAM 3500 Cab Chassis	2014	TCM (Transmission Control Module)																																														
RAM 3500 Cab Chassis	2013	PCM (Powertrain Control Module)																																														
RAM 3500 Cab Chassis	2013	ABS (Anti Lock Brake System)	V																																													
RAM 3500 Cab Chassis	2013	AMP (Audio)																						V	V																							
RAM 3500 Cab Chassis	2013	DDM (Drivers Door Module)																					V																									
RAM 3500 Cab Chassis	2013	DTCM (Drive Train Control Module)																																														
RAM 3500 Cab Chassis	2013	HSM (Heated Seat Module)																																														
RAM 3500 Cab Chassis	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 3500 Cab Chassis	2013	ORC (Occupant Restraint Control)		V																																												
RAM 3500 Cab Chassis	2013	PDM (Passenger Door Module)																																														
RAM 3500 Cab Chassis	2013	PTS (Park Assist Module)																																														
RAM 3500 Cab Chassis	2013	RADIO (Radio)																																				V	V	V	V							
RAM 3500 Cab Chassis	2013	TCM (Transmission Control Module)																																														
RAM 3500 Cab Chassis	2012	PCM (Powertrain Control Module)																																														
RAM 3500 Cab Chassis	2012	ABS (Anti Lock Brake System)	V																																													
RAM 3500 Cab Chassis	2012	AMP (Audio)																						V	V																							
RAM 3500 Cab Chassis	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 3500 Cab Chassis	2012	DDM (Drivers Door Module)																					V																									
RAM 3500 Cab Chassis	2012	DTCM (Drive Train Control Module)																																														
RAM 3500 Cab Chassis	2012	HFM (Hands Free Module)																																								V						
RAM 3500 Cab Chassis	2012	HSM (Heated Seat Module)																																														
RAM 3500 Cab Chassis	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 3500 Cab Chassis	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 3500 Cab Chassis	2012	ORC (Occupant Restraint Control)		V																																												
RAM 3500 Cab Chassis	2012	RADIO (Radio)																																				V	V	V	V							
RAM 3500 Cab Chassis	2012	SAS (Steering Angle Sensor)																																														
RAM 3500 Cab Chassis	2012	TCM (Transmission Control Module)																																														
RAM 3500 Cab Chassis	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
RAM 3500 Cab Chassis	2012	WCM(Wireless Control Modules)														V																											V	V				
RAM 3500 Cab Chassis	2011	PCM (Powertrain Control Module)																																														
RAM 3500 Cab Chassis	2011	ABS (Anti Lock Brake System)	V																																													
RAM 3500 Cab Chassis	2011	AMP (Audio)																						V	V																							
RAM 3500 Cab Chassis	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 3500 Cab Chassis	2011	DDM (Drivers Door Module)																					V																									
RAM 3500 Cab Chassis	2011	DTCM (Drive Train Control Module)																																														
RAM 3500 Cab Chassis	2011	HFM (Hands Free Module)																																								V						
RAM 3500 Cab Chassis	2011	HSM (Heated Seat Module)																																														
RAM 3500 Cab Chassis	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 3500 Cab Chassis	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 3500 Cab Chassis	2011	ORC (Occupant Restraint Control)		V																																												

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 3500 Cab Chassis	2011	RADIO (Radio)																																					V	V	V	V						
RAM 3500 Cab Chassis	2011	SAS (Steering Angle Sensor)																																														
RAM 3500 Cab Chassis	2011	TCM (Transmission Control Module)																																														
RAM 3500 Cab Chassis	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
RAM 3500 Cab Chassis	2011	WCM(Wireless Control Modules)														V																											V	V				
RAM 4500	2016	PCM (Powertrain Control Module)																																														
RAM 4500	2016	ABS (Anti Lock Brake System)																																														
RAM 4500	2016	AMP (Audio)																																														
RAM 4500	2016	BCM (Body Control Module)																																														
RAM 4500	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RAM 4500	2016	CGW (Central Gateway)																																														
RAM 4500	2016	DDM (Drivers Door Module)																																														
RAM 4500	2016	DTCM (Drive Train Control Module)																																														
RAM 4500	2016	EDM (Electronic Damper Module)																																														
RAM 4500	2016	EPS (Electric Power Steering)																																														
RAM 4500	2016	ESM (Electronic Shifter Module)																																														
RAM 4500	2016	HSM (Heated Seat Module)																																														
RAM 4500	2016	HVAC (Heat Vent A/C)																																														
RAM 4500	2016	ICS (Integrated Center Stack)																																														
RAM 4500	2016	IPC (Instrument Panel Cluster)																																														
RAM 4500	2016	MSMD (Memory Seet Module)																																														
RAM 4500	2016	ORC (Occupant Restraint Control)																																														
RAM 4500	2016	PDM (Passenger Door Module)																																														
RAM 4500	2016	PTS (Park Assist Module)																																														
RAM 4500	2016	RADIO (Radio)																																														
RAM 4500	2016	RFH (Radio Frequency Hub)																																														
RAM 4500	2016	SCM (Steering Column Module)																																														
RAM 4500	2016	TCM (Transmission Control Module)																																														
RAM 4500	2016	WCM(Wireless Control Modules)																																														
RAM 4500	2015	PCM (Powertrain Control Module)																																														
RAM 4500	2015	ABS (Anti Lock Brake System)																																														
RAM 4500	2015	AMP (Audio)																																														
RAM 4500	2015	BCM (Body Control Module)																																														
RAM 4500	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RAM 4500	2015	CGW (Central Gateway)																																														
RAM 4500	2015	DDM (Drivers Door Module)																																														
RAM 4500	2015	DTCM (Drive Train Control Module)																																														
RAM 4500	2015	EDM (Electronic Damper Module)																																														
RAM 4500	2015	EPS (Electric Power Steering)																																														
RAM 4500	2015	ESM (Electronic Shifter Module)																																														
RAM 4500	2015	HSM (Heated Seat Module)																																														
RAM 4500	2015	HVAC (Heat Vent A/C)																																														
RAM 4500	2015	ICS (Integrated Center Stack)																																														
RAM 4500	2015	IPC (Instrument Panel Cluster)																																														
RAM 4500	2015	MSMD (Memory Seet Module)																																														
RAM 4500	2015	ORC (Occupant Restraint Control)																																														
RAM 4500	2015	PDM (Passenger Door Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 4500	2015	PTS (Park Assist Module)																																														
RAM 4500	2015	RADIO (Radio)																																														
RAM 4500	2015	RFH (Radio Frequency Hub)																																														
RAM 4500	2015	SCM (Steering Column Module)																																														
RAM 4500	2015	TCM (Transmission Control Module)																																														
RAM 4500	2015	WCM(Wireless Control Modules)																																														
RAM 4500	2014	PCM (Powertrain Control Module)																																														
RAM 4500	2014	ABS (Anti Lock Brake System)	V																																													
RAM 4500	2014	AMP (Audio)																						V	V																							
RAM 4500	2014	DDM (Drivers Door Module)																					V																									
RAM 4500	2014	DTCM (Drive Train Control Module)																																														
RAM 4500	2014	HSM (Heated Seat Module)																																														
RAM 4500	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 4500	2014	ORC (Occupant Restraint Control)		V																																												
RAM 4500	2014	PDM (Passenger Door Module)																																														
RAM 4500	2014	PTS (Park Assist Module)																																														
RAM 4500	2014	RADIO (Radio)																																					V	V	V	V						
RAM 4500	2014	TCM (Transmission Control Module)																																														
RAM 4500	2013	PCM (Powertrain Control Module)																																														
RAM 4500	2013	ABS (Anti Lock Brake System)	V																																													
RAM 4500	2013	AMP (Audio)																						V	V																							
RAM 4500	2013	DDM (Drivers Door Module)																					V																									
RAM 4500	2013	DTCM (Drive Train Control Module)																																														
RAM 4500	2013	HSM (Heated Seat Module)																																														
RAM 4500	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 4500	2013	ORC (Occupant Restraint Control)		V																																												
RAM 4500	2013	PDM (Passenger Door Module)																																														
RAM 4500	2013	PTS (Park Assist Module)																																														
RAM 4500	2013	RADIO (Radio)																																					V	V	V	V						
RAM 4500	2013	TCM (Transmission Control Module)																																														
RAM 4500	2012	PCM (Powertrain Control Module)																																														
RAM 4500	2012	ABS (Anti Lock Brake System)	V																																													
RAM 4500	2012	AMP (Audio)																						V	V																							
RAM 4500	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 4500	2012	DTCM (Drive Train Control Module)																																														
RAM 4500	2012	HFM (Hands Free Module)																																								V						
RAM 4500	2012	HSM (Heated Seat Module)																																														
RAM 4500	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 4500	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 4500	2012	ORC (Occupant Restraint Control)		V																																												
RAM 4500	2012	RADIO (Radio)																																					V	V	V	V						
RAM 4500	2012	SAS (Steering Angle Sensor)																																														
RAM 4500	2012	TCM (Transmission Control Module)																																														
RAM 4500	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
RAM 4500	2012	WCM(Wireless Control Modules)														V																											V	V				
RAM 4500	2011	PCM (Powertrain Control Module)																																														
RAM 4500	2011	ABS (Anti Lock Brake System)	V																																													

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 4500	2011	AMP (Audio)																						V	V																							
RAM 4500	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 4500	2011	DTCM (Drive Train Control Module)																																														
RAM 4500	2011	HFM (Hands Free Module)																																								V						
RAM 4500	2011	HSM (Heated Seat Module)																																														
RAM 4500	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 4500	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 4500	2011	ORC (Occupant Restraint Control)		V																																												
RAM 4500	2011	RADIO (Radio)																																				V	V	V	V							
RAM 4500	2011	SAS (Steering Angle Sensor)																																														
RAM 4500	2011	TCM (Transmission Control Module)																																														
RAM 4500	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
RAM 4500	2011	WCM(Wireless Control Modules)														V																											V	V				
RAM 5500	2016	PCM (Powertrain Control Module)																																														
RAM 5500	2016	ABS (Anti Lock Brake System)																																														
RAM 5500	2016	AMP (Audio)																																														
RAM 5500	2016	BCM (Body Control Module)																																														
RAM 5500	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RAM 5500	2016	CGW (Central Gateway)																																														
RAM 5500	2016	DDM (Drivers Door Module)																																														
RAM 5500	2016	DTCM (Drive Train Control Module)																																														
RAM 5500	2016	EDM (Electronic Damper Module)																																														
RAM 5500	2016	EPS (Electric Power Steering)																																														
RAM 5500	2016	ESM (Electronic Shifter Module)																																														
RAM 5500	2016	HSM (Heated Seat Module)																																														
RAM 5500	2016	HVAC (Heat Vent A/C)																																														
RAM 5500	2016	ICS (Integrated Center Stack)																																														
RAM 5500	2016	IPC (Instrument Panel Cluster)																																														
RAM 5500	2016	MSMD (Memory Seet Module)																																														
RAM 5500	2016	ORC (Occupant Restraint Control)																																														
RAM 5500	2016	PDM (Passenger Door Module)																																														
RAM 5500	2016	PTS (Park Assist Module)																																														
RAM 5500	2016	RADIO (Radio)																																														
RAM 5500	2016	RFH (Radio Frequency Hub)																																														
RAM 5500	2016	SCM (Steering Column Module)																																														
RAM 5500	2016	TCM (Transmission Control Module)																																														
RAM 5500	2016	WCM(Wireless Control Modules)																																														
RAM 5500	2015	PCM (Powertrain Control Module)																																														
RAM 5500	2015	ABS (Anti Lock Brake System)																																														
RAM 5500	2015	AMP (Audio)																																														
RAM 5500	2015	BCM (Body Control Module)																																														
RAM 5500	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RAM 5500	2015	CGW (Central Gateway)																																														
RAM 5500	2015	DDM (Drivers Door Module)																																														
RAM 5500	2015	DTCM (Drive Train Control Module)																																														
RAM 5500	2015	EDM (Electronic Damper Module)																																														
RAM 5500	2015	EPS (Electric Power Steering)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 5500	2015	ESM (Electronic Shifter Module)																																														
RAM 5500	2015	HSM (Heated Seat Module)																																														
RAM 5500	2015	HVAC (Heat Vent A/C)																																														
RAM 5500	2015	ICS (Integrated Center Stack)																																														
RAM 5500	2015	IPC (Instrument Panel Cluster)																																														
RAM 5500	2015	MSMD (Memory Seet Module)																																														
RAM 5500	2015	ORC (Occupant Restraint Control)																																														
RAM 5500	2015	PDM (Passenger Door Module)																																														
RAM 5500	2015	PTS (Park Assist Module)																																														
RAM 5500	2015	RADIO (Radio)																																														
RAM 5500	2015	RFH (Radio Frequency Hub)																																														
RAM 5500	2015	SCM (Steering Column Module)																																														
RAM 5500	2015	TCM (Transmission Control Module)																																														
RAM 5500	2015	WCM(Wireless Control Modules)																																														
RAM 5500	2014	PCM (Powertrain Control Module)																																														
RAM 5500	2014	ABS (Anti Lock Brake System)	V																																													
RAM 5500	2014	AMP (Audio)																						V	V																							
RAM 5500	2014	DDM (Drivers Door Module)																					V																									
RAM 5500	2014	DTCM (Drive Train Control Module)																																														
RAM 5500	2014	HSM (Heated Seat Module)																																														
RAM 5500	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 5500	2014	ORC (Occupant Restraint Control)		V																																												
RAM 5500	2014	PDM (Passenger Door Module)																																														
RAM 5500	2014	PTS (Park Assist Module)																																														
RAM 5500	2014	RADIO (Radio)																																					V	V	V	V						
RAM 5500	2014	TCM (Transmission Control Module)																																														
RAM 5500	2013	PCM (Powertrain Control Module)																																														
RAM 5500	2013	ABS (Anti Lock Brake System)	V																																													
RAM 5500	2013	AMP (Audio)																						V	V																							
RAM 5500	2013	DDM (Drivers Door Module)																					V																									
RAM 5500	2013	DTCM (Drive Train Control Module)																																														
RAM 5500	2013	HSM (Heated Seat Module)																																														
RAM 5500	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 5500	2013	ORC (Occupant Restraint Control)		V																																												
RAM 5500	2013	PDM (Passenger Door Module)																																														
RAM 5500	2013	PTS (Park Assist Module)																																														
RAM 5500	2013	RADIO (Radio)																																					V	V	V	V						
RAM 5500	2013	TCM (Transmission Control Module)																																														
RAM 5500	2012	PCM (Powertrain Control Module)																																														
RAM 5500	2012	ABS (Anti Lock Brake System)	V																																													
RAM 5500	2012	AMP (Audio)																						V	V																							
RAM 5500	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 5500	2012	DTCM (Drive Train Control Module)																																														
RAM 5500	2012	HFM (Hands Free Module)																																								V						
RAM 5500	2012	HSM (Heated Seat Module)																																														
RAM 5500	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 5500	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM 5500	2012	ORC (Occupant Restraint Control)		V																																												
RAM 5500	2012	RADIO (Radio)																																				V	V	V	V							
RAM 5500	2012	SAS (Steering Angle Sensor)																																														
RAM 5500	2012	TCM (Transmission Control Module)																																														
RAM 5500	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
RAM 5500	2012	WCM(Wireless Control Modules)														V																											V	V				
RAM 5500	2011	PCM (Powertrain Control Module)																																														
RAM 5500	2011	ABS (Anti Lock Brake System)	V																																													
RAM 5500	2011	AMP (Audio)																						V	V																							
RAM 5500	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM 5500	2011	DTCM (Drive Train Control Module)																																														
RAM 5500	2011	HFM (Hands Free Module)																																								V						
RAM 5500	2011	HSM (Heated Seat Module)																																														
RAM 5500	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM 5500	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM 5500	2011	ORC (Occupant Restraint Control)		V																																												
RAM 5500	2011	RADIO (Radio)																																				V	V	V	V							
RAM 5500	2011	SAS (Steering Angle Sensor)																																														
RAM 5500	2011	TCM (Transmission Control Module)																																														
RAM 5500	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
RAM 5500	2011	WCM(Wireless Control Modules)														V																											V	V				
RAM (Mexico)	2016	PCM (Powertrain Control Module)																																														
RAM (Mexico)	2016	ABS (Anti Lock Brake System)																																														
RAM (Mexico)	2016	AMP (Audio)																																														
RAM (Mexico)	2016	BCM (Body Control Module)																																														
RAM (Mexico)	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RAM (Mexico)	2016	CGW (Central Gateway)																																														
RAM (Mexico)	2016	DDM (Drivers Door Module)																																														
RAM (Mexico)	2016	DTCM (Drive Train Control Module)																																														
RAM (Mexico)	2016	EDM (Electronic Damper Module)																																														
RAM (Mexico)	2016	EPS (Electric Power Steering)																																														
RAM (Mexico)	2016	ESM (Electronic Shifter Module)																																														
RAM (Mexico)	2016	HSM (Heated Seat Module)																																														
RAM (Mexico)	2016	HVAC (Heat Vent A/C)																																														
RAM (Mexico)	2016	ICS (Integrated Center Stack)																																														
RAM (Mexico)	2016	IPC (Instrument Panel Cluster)																																														
RAM (Mexico)	2016	MSMD (Memory Seet Module)																																														
RAM (Mexico)	2016	ORC (Occupant Restraint Control)																																														
RAM (Mexico)	2016	PDM (Passenger Door Module)																																														
RAM (Mexico)	2016	PTS (Park Assist Module)																																														
RAM (Mexico)	2016	RADIO (Radio)																																														
RAM (Mexico)	2016	RFH (Radio Frequency Hub)																																														
RAM (Mexico)	2016	SCM (Steering Column Module)																																														
RAM (Mexico)	2016	TCM (Transmission Control Module)																																														
RAM (Mexico)	2016	WCM(Wireless Control Modules)																																														
RAM (Mexico)	2015	PCM (Powertrain Control Module)																																														
RAM (Mexico)	2015	ABS (Anti Lock Brake System)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM (Mexico)	2015	AMP (Audio)																																														
RAM (Mexico)	2015	BCM (Body Control Module)																																														
RAM (Mexico)	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RAM (Mexico)	2015	CGW (Central Gateway)																																														
RAM (Mexico)	2015	DDM (Drivers Door Module)																																														
RAM (Mexico)	2015	DTCM (Drive Train Control Module)																																														
RAM (Mexico)	2015	EDM (Electronic Damper Module)																																														
RAM (Mexico)	2015	EPS (Electric Power Steering)																																														
RAM (Mexico)	2015	ESM (Electronic Shifter Module)																																														
RAM (Mexico)	2015	HSM (Heated Seat Module)																																														
RAM (Mexico)	2015	HVAC (Heat Vent A/C)																																														
RAM (Mexico)	2015	ICS (Integrated Center Stack)																																														
RAM (Mexico)	2015	IPC (Instrument Panel Cluster)																																														
RAM (Mexico)	2015	MSMD (Memory Seet Module)																																														
RAM (Mexico)	2015	ORC (Occupant Restraint Control)																																														
RAM (Mexico)	2015	PDM (Passenger Door Module)																																														
RAM (Mexico)	2015	PTS (Park Assist Module)																																														
RAM (Mexico)	2015	RADIO (Radio)																																														
RAM (Mexico)	2015	RFH (Radio Frequency Hub)																																														
RAM (Mexico)	2015	SCM (Steering Column Module)																																														
RAM (Mexico)	2015	TCM (Transmission Control Module)																																														
RAM (Mexico)	2015	WCM(Wireless Control Modules)																																														
RAM (Mexico)	2014	PCM (Powertrain Control Module)																																														
RAM (Mexico)	2014	ABS (Anti Lock Brake System)	V																																													
RAM (Mexico)	2014	AMP (Audio)																						V	V																							
RAM (Mexico)	2014	DDM (Drivers Door Module)																					V																									
RAM (Mexico)	2014	DTCM (Drive Train Control Module)																																														
RAM (Mexico)	2014	ESM (Electronic Shifter Module)																																														
RAM (Mexico)	2014	HSM (Heated Seat Module)																																														
RAM (Mexico)	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM (Mexico)	2014	ORC (Occupant Restraint Control)		V																																												
RAM (Mexico)	2014	PDM (Passenger Door Module)																																														
RAM (Mexico)	2014	PTS (Park Assist Module)																																														
RAM (Mexico)	2014	RADIO (Radio)																																				V	V	V	V							
RAM (Mexico)	2014	TCM (Transmission Control Module)																																														
RAM (Mexico)	2013	PCM (Powertrain Control Module)																																														
RAM (Mexico)	2013	ABS (Anti Lock Brake System)	V																																													
RAM (Mexico)	2013	AMP (Audio)																						V	V																							
RAM (Mexico)	2013	DDM (Drivers Door Module)																					V																									
RAM (Mexico)	2013	DTCM (Drive Train Control Module)																																														
RAM (Mexico)	2013	ESM (Electronic Shifter Module)																																														
RAM (Mexico)	2013	HSM (Heated Seat Module)																																														
RAM (Mexico)	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM (Mexico)	2013	ORC (Occupant Restraint Control)		V																																												
RAM (Mexico)	2013	PDM (Passenger Door Module)																																														
RAM (Mexico)	2013	PTS (Park Assist Module)																																														
RAM (Mexico)	2013	RADIO (Radio)																																				V	V	V	V							

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM (Mexico)	2013	TCM (Transmission Control Module)																																														
RAM (Mexico)	2013	TPM (Tire Pressure Monitor)																																														
RAM (Mexico)	2012	PCM (Powertrain Control Module)																																														
RAM (Mexico)	2012	ABS (Anti Lock Brake System)	V																																													
RAM (Mexico)	2012	AMP (Audio)																						V	V																							
RAM (Mexico)	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM (Mexico)	2012	DTCM (Drive Train Control Module)																																														
RAM (Mexico)	2012	HFM (Hands Free Module)																																								V						
RAM (Mexico)	2012	HSM (Heated Seat Module)																																														
RAM (Mexico)	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM (Mexico)	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM (Mexico)	2012	ORC (Occupant Restraint Control)		V																																												
RAM (Mexico)	2012	PTS (Park Assist Module)																																														
RAM (Mexico)	2012	RADIO (Radio)																																				V	V	V	V							
RAM (Mexico)	2012	SAS (Steering Angle Sensor)																																														
RAM (Mexico)	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
RAM (Mexico)	2012	TPM (Tire Pressure Monitor)																																														
RAM (Mexico)	2012	VES3 (Vidio Entertainment System 3)																																														
RAM (Mexico)	2012	WCM(Wireless Control Modules)														V																											V	V				
RAM (Mexico)	2011	PCM (Powertrain Control Module)																																														
RAM (Mexico)	2011	ABS (Anti Lock Brake System)	V																																													
RAM (Mexico)	2011	AMP (Audio)																						V	V																							
RAM (Mexico)	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM (Mexico)	2011	DTCM (Drive Train Control Module)																																														
RAM (Mexico)	2011	HFM (Hands Free Module)																																								V						
RAM (Mexico)	2011	HSM (Heated Seat Module)																																														
RAM (Mexico)	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM (Mexico)	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM (Mexico)	2011	ORC (Occupant Restraint Control)		V																																												
RAM (Mexico)	2011	PTS (Park Assist Module)																																														
RAM (Mexico)	2011	RADIO (Radio)																																				V	V	V	V							
RAM (Mexico)	2011	SAS (Steering Angle Sensor)																																														
RAM (Mexico)	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
RAM (Mexico)	2011	TPM (Tire Pressure Monitor)																																														
RAM (Mexico)	2011	VES3 (Vidio Entertainment System 3)																																														
RAM (Mexico)	2011	WCM(Wireless Control Modules)														V																											V	V				
RAM (Mexico)	2010	PCM (Powertrain Control Module)																																														
RAM (Mexico)	2010	ABS (Anti Lock Brake System)	V																																													
RAM (Mexico)	2010	AMP (Audio)																						V	V																							
RAM (Mexico)	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAM (Mexico)	2010	DTCM (Drive Train Control Module)																																														
RAM (Mexico)	2010	HFM (Hands Free Module)																																								V						
RAM (Mexico)	2010	HSM (Heated Seat Module)																																														
RAM (Mexico)	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAM (Mexico)	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
RAM (Mexico)	2010	ORC (Occupant Restraint Control)		V																																												
RAM (Mexico)	2010	PTS (Park Assist Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAM (Mexico)	2010	RADIO (Radio)																																				V	V	V	V							
RAM (Mexico)	2010	SAS (Steering Angle Sensor)																																														
RAM (Mexico)	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
RAM (Mexico)	2010	TPM (Tire Pressure Monitor)																																														
RAM (Mexico)	2010	VES3 (Vidio Entertainment System 3)																																														
RAM (Mexico)	2010	WCM(Wireless Control Modules)														V																											V	V				
DART	2016	PCM (Powertrain Control Module)																																														
DART	2016	ABS (Anti Lock Brake System)																																														
DART	2016	AMP (Audio)																																														
DART	2016	BCM (Body Control Module)																																														
DART	2016	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
DART	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
DART	2016	CGW (Central Gateway)																																														
DART	2016	EDM (Electronic Damper Module)																																														
DART	2016	EPS (Electric Power Steering)																																														
DART	2016	ESM (Electronic Shifter Module)																																														
DART	2016	HVAC (Heat Vent A/C)																																														
DART	2016	ICS (Integrated Center Stack)																																														
DART	2016	IPC (Instrument Panel Cluster)																																														
DART	2016	LBSS (Left Blind Spot Sensor)																																														
DART	2016	OCM (Occupant Classification Module)																																														
DART	2016	ORC (Occupant Restraint Control)																																														
DART	2016	RADIO (Radio)																																														
DART	2016	RBSS (Right Blind Spot Sensor)																																														
DART	2016	RFH (Radio Frequency Hub)																																														
DART	2016	SCM (Steering Column Module)																																														
DART	2016	TCM (Transmission Control Module)																																														
DART	2016	WCM(Wireless Control Modules)																																														
DART	2015	PCM (Powertrain Control Module)																																														
DART	2015	ABS (Anti Lock Brake System)																																														
DART	2015	AMP (Audio)																																														
DART	2015	BCM (Body Control Module)																																														
DART	2015	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
DART	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
DART	2015	CGW (Central Gateway)																																														
DART	2015	EDM (Electronic Damper Module)																																														
DART	2015	EPS (Electric Power Steering)																																														
DART	2015	ESM (Electronic Shifter Module)																																														
DART	2015	HVAC (Heat Vent A/C)																																														
DART	2015	ICS (Integrated Center Stack)																																														
DART	2015	IPC (Instrument Panel Cluster)																																														
DART	2015	LBSS (Left Blind Spot Sensor)																																														
DART	2015	OCM (Occupant Classification Module)																																														
DART	2015	ORC (Occupant Restraint Control)																																														
DART	2015	RADIO (Radio)																																														
DART	2015	RBSS (Right Blind Spot Sensor)																																														
DART	2015	RFH (Radio Frequency Hub)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
DART	2015	SCM (Steering Column Module)																																														
DART	2015	TCM (Transmission Control Module)																																														
DART	2015	WCM(Wireless Control Modules)																																														
DART	2014	PCM (Powertrain Control Module)																																														
DART	2014	ABS (Anti Lock Brake System)																																														
DART	2014	AMP (Audio)																																														
DART	2014	BCM (Body Control Module)																																														
DART	2014	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
DART	2014	CCN (Instrument Cluster / Cabin Compartment Node)																																														
DART	2014	CGW (Central Gateway)																																														
DART	2014	EDM (Electronic Damper Module)																																														
DART	2014	EPS (Electric Power Steering)																																														
DART	2014	ESM (Electronic Shifter Module)																																														
DART	2014	HVAC (Heat Vent A/C)																																														
DART	2014	ICS (Integrated Center Stack)																																														
DART	2014	IPC (Instrument Panel Cluster)																																														
DART	2014	LBSS (Left Blind Spot Sensor)																																														
DART	2014	OCM (Occupant Classification Module)																																														
DART	2014	ORC (Occupant Restraint Control)																																														
DART	2014	RADIO (Radio)																																														
DART	2014	RBSS (Right Blind Spot Sensor)																																														
DART	2014	RFH (Radio Frequency Hub)																																														
DART	2014	SCM (Steering Column Module)																																														
DART	2014	TCM (Transmission Control Module)																																														
DART	2014	WCM(Wireless Control Modules)																																														
DART	2013	PCM (Powertrain Control Module)																																														
DART	2013	ABS (Anti Lock Brake System)																																														
DART	2013	AMP (Audio)																																														
DART	2013	BCM (Body Control Module)																																														
DART	2013	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
DART	2013	CCN (Instrument Cluster / Cabin Compartment Node)																																														
DART	2013	CGW (Central Gateway)																																														
DART	2013	EDM (Electronic Damper Module)																																														
DART	2013	EPS (Electric Power Steering)																																														
DART	2013	ESM (Electronic Shifter Module)																																														
DART	2013	HVAC (Heat Vent A/C)																																														
DART	2013	ICS (Integrated Center Stack)																																														
DART	2013	IPC (Instrument Panel Cluster)																																														
DART	2013	LBSS (Left Blind Spot Sensor)																																														
DART	2013	OCM (Occupant Classification Module)																																														
DART	2013	ORC (Occupant Restraint Control)																																														
DART	2013	RADIO (Radio)																																														
DART	2013	RBSS (Right Blind Spot Sensor)																																														
DART	2013	RFH (Radio Frequency Hub)																																														
DART	2013	SCM (Steering Column Module)																																														
DART	2013	TCM (Transmission Control Module)																																														
DART	2013	WCM(Wireless Control Modules)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
DART	2012	PCM (Powertrain Control Module)																																														
DART	2012	ABS (Anti Lock Brake System)																																														
DART	2012	AMP (Audio)																																														
DART	2012	BCM (Body Control Module)																																														
DART	2012	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
DART	2012	CCN (Instrument Cluster / Cabin Compartment Node)																																														
DART	2012	CGW (Central Gateway)																																														
DART	2012	EDM (Electronic Damper Module)																																														
DART	2012	EPS (Electric Power Steering)																																														
DART	2012	ESM (Electronic Shifter Module)																																														
DART	2012	HVAC (Heat Vent A/C)																																														
DART	2012	ICS (Integrated Center Stack)																																														
DART	2012	IPC (Instrument Panel Cluster)																																														
DART	2012	LBSS (Left Blind Spot Sensor)																																														
DART	2012	OCM (Occupant Classification Module)																																														
DART	2012	ORC (Occupant Restraint Control)																																														
DART	2012	RADIO (Radio)																																														
DART	2012	RBSS (Right Blind Spot Sensor)																																														
DART	2012	RFH (Radio Frequency Hub)																																														
DART	2012	SCM (Steering Column Module)																																														
DART	2012	TCM (Transmission Control Module)																																														
DART	2012	WCM(Wireless Control Modules)																																														
VIPER	2016	PCM (Powertrain Control Module)																																														
VIPER	2016	ABS (Anti Lock Brake System)																																														
VIPER	2016	ADCM (Adaptive Damper Control Module)																																														
VIPER	2016	AMP (Audio)																																														
VIPER	2016	BCM (Body Control Module)																																														
VIPER	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
VIPER	2016	CGW (Central Gateway)																																														
VIPER	2016	DDM (Drivers Door Module)																																														
VIPER	2016	HVAC (Heat Vent A/C)																																														
VIPER	2016	ICS (Integrated Center Stack)																																														
VIPER	2016	IPC (Instrument Panel Cluster)																																														
VIPER	2016	OCM (Occupant Classification Module)																																														
VIPER	2016	ORC (Occupant Restraint Control)																																														
VIPER	2016	PDM (Passenger Door Module)																																														
VIPER	2016	RADIO (Radio)																																														
VIPER	2016	RFH (Radio Frequency Hub)																																														
VIPER	2016	SCM (Steering Column Module)																																														
VIPER	2016	TPM (Tire Pressure Monitor)																																														
VIPER	2016	WCM(Wireless Control Modules)																																														
VIPER	2015	PCM (Powertrain Control Module)																																														
VIPER	2015	ABS (Anti Lock Brake System)																																														
VIPER	2015	ADCM (Adaptive Damper Control Module)																																														
VIPER	2015	AMP (Audio)																																														
VIPER	2015	BCM (Body Control Module)																																														
VIPER	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
VIPER	2015	CGW (Central Gateway)																																														
VIPER	2015	DDM (Drivers Door Module)																																														
VIPER	2015	HVAC (Heat Vent A/C)																																														
VIPER	2015	ICS (Integrated Center Stack)																																														
VIPER	2015	IPC (Instrument Panel Cluster)																																														
VIPER	2015	OCM (Occupant Classification Module)																																														
VIPER	2015	ORC (Occupant Restraint Control)																																														
VIPER	2015	PDM (Passenger Door Module)																																														
VIPER	2015	RADIO (Radio)																																														
VIPER	2015	RFH (Radio Frequency Hub)																																														
VIPER	2015	SCM (Steering Column Module)																																														
VIPER	2015	TPM (Tire Pressure Monitor)																																														
VIPER	2015	WCM(Wireless Control Modules)																																														
VIPER	2014	PCM (Powertrain Control Module)																																														
VIPER	2014	ABS (Anti Lock Brake System)	V																																													
VIPER	2014	AMP (Audio)																						V	V																							
VIPER	2014	DDM (Drivers Door Module)																					V																									
VIPER	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
VIPER	2014	OCM (Occupant Classification Module)																																														
VIPER	2014	ORC (Occupant Restraint Control)		V																																												
VIPER	2014	PDM (Passenger Door Module)																																														
VIPER	2014	RADIO (Radio)																																					V	V	V	V						
VIPER	2014	TPM (Tire Pressure Monitor)																																														
VIPER	2013	PCM (Powertrain Control Module)																																														
VIPER	2013	ABS (Anti Lock Brake System)	V																																													
VIPER	2013	AMP (Audio)																						V	V																							
VIPER	2013	DDM (Drivers Door Module)																					V																									
VIPER	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
VIPER	2013	OCM (Occupant Classification Module)																																														
VIPER	2013	ORC (Occupant Restraint Control)		V																																												
VIPER	2013	PDM (Passenger Door Module)																																														
VIPER	2013	RADIO (Radio)																																					V	V	V	V						
VIPER	2013	TPM (Tire Pressure Monitor)																																														
VIPER	2012	ORC (Occupant Restraint Control)																																														
VIPER	2012	PDM (Passenger Door Module)																																														
VIPER	2012	RADIO (Radio)																																					V	V	V	V						
VIPER	2012	TPM (Tire Pressure Monitor)																																														
VIPER	2010	PCM (Powertrain Control Module)																																														
VIPER	2010	OCM (Occupant Classification Module)																																														
VIPER	2009	PCM (Powertrain Control Module)																																														
VIPER	2009	OCM (Occupant Classification Module)																																														
VIPER	2008	PCM (Powertrain Control Module)																																														
VIPER	2008	OCM (Occupant Classification Module)																																														

Model	System	System2	DTC Analysis	DTC Erase	Data Analysis	Actuation Test	ECU Information Display	Flap actuators learning	Vehicle configuration reset	Gearbox lever position learn	Key programming	Remote programming	Engine service reset type#1	Engine service reset type#2	Oil change (only for version with DPF)	Tow hook	Next service reset	Steering angle	Lateral and longitudinal acceleration sensor calibration	Steering angle calibration	Reset steering angle	Longitudinal acceleration sensor calibration	Yaw sensor calibration	Lateral acceleration sensor calibration	Pressure sensor calibration	Power Supply Mode (Logistic Mode)	Indicators command	Power supply mode	Rearm inertia switch(FIS)	Activate seat belt alarm	Torque/position calibrations reset	Position sensor calibration	Torque sensor calibration	System calibration	Replacement of UniAir module	Replacement of timing sensor or cam	UniAir actuator dispersion correction	Replacement of RPM sensor or distribution belt	Replacement of oil temperature sensor
Support function	Key programming	Type1	V	V			V				V																												
		Type2	V	V			V				V																												
		Type3	V	V			V				V	V																											
	Service reset engine	Type1											V	V																									
		Type2													V																								
	Service reset instrument	Type1															V																						
		Type2															V																						
		Type3															V																						
		Type4															V																						
		Type5															V																						
Engine		Bosch Motronic MeD 7.6.1 CF4/EOBD Injection(1.9, 2.2)	V	V	V	V	V																																
		Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	V	V	V	V	V																																
		Bosch EDC16C39 CF4/EOBD Diesel Injection (2.3, 3.0)	V	V	V	V	V																																
		Marelli 6F3 EOBD Diesel Injection (1.3)	V	V	V	V	V																																
		Bosch Motronic Me7.3.1 EOBD Injection	V	V	V	V	V																																
		Bosch EDC15C7 CF3/EOBD Diesel Injection (1.9, 2.4)	V	V	V	V	V																																
		Bosch EDC16C39 CF4/EOBD Diesel Injection (1.9, 2.4)	V	V	V	V	V																																
		Bosch Motronic MED7.11 EOBD Injection	V	V	V	V	V																																
		Magneti Marelli IAW 5NF EOBD Injection	V	V	V	V	V		V																														
		Bosch Motronic Me7.9.10 CF5/EOBD Injection (1.4)	V	V	V	V	V																																
		Delphi MT27E Injection (1.8)	V	V	V	V	V		V																														
		Magneti Marelli IAW 4SF Injection	V	V	V	V	V		V																														
		Magneti Marelli IAW 5SF CF4/EOBD Injection (1.4 8V)	V	V	V	V	V																																
		Magneti Marelli IAW 5SF8 CF5/EOBD Injection (8V)	V	V	V	V	V																																
		Marelli 6F3 EOBD Diesel Injection	V	V	V	V	V																																
		Bosch Motronic MeD17.3.1 CF5/EOBD Injection (1.8)	V	V	V	V	V																																
		Marelli 8F3 CF5/EOBD Diesel Injection (1.3)	V	V	V	V	V																																
		Magneti Marelli IAW 5SF3 CF4/EOBD Injection (8V)	V	V	V	V	V																																
		Marelli 8DF CF5/EOBD Diesel Injection (1.3)	V	V	V	V	V																																
		Magneti Marelli IAW 8GMF CF5/EOBD Injection (1.4 16V)	V	V	V	V	V																											V	V	V	V	V
		Bosch EDC17CP52 CF5/EOBD Diesel Injection (3.0)	V	V	V	V	V								V																								
		Magneti Marelli IAW 8GMW CF5/EOBD Injection (1.4)	V	V	V	V	V																											V	V	V	V	V
		Basic system	V	V			V																																
		Basic system	V	V			V																																
		Basic system	V	V			V																																
	AT	Marelli selespeed CFC300	V	V	V	V	V																																
		Marelli SELESPEED CFC348 Automatic Gearbox	V	V	V	V	V																																
		Marelli SELESPEED CFC218F GTA Automatic Gearbox	V	V	V	V	V																																
		Marelli SELESPEED CFC300 Automatic Gearbox	V	V	V	V	V																																
		Marelli SELESPEED CFC328 Automatic Gearbox	V	V	V	V	V																																

Model	System	System2	DTC Analysis	DTC Erase	Data Analysis	Actuation Test	ECU Information Display	Flap actuators learning	Vehicle configuration reset	Gearbox lever position learn	Key programming	Remote programming	Engine service reset type#1	Engine service reset type#2	Oil change (only for version with DPF)	Tow hook	Next service reset	Steering angle	Lateral and longitudinal acceleration sensor calibration	Steering angle calibration	Reset steering angle	Longitudinal acceleration sensor calibration	Yaw sensor calibration	Lateral acceleration sensor calibration	Pressure sensor calibration	Power Supply Mode (Logistic Mode)	Indicators command	Power supply mode	Rearm inertia switch(FIS)	Activate seat belt alarm	Torque/position calibrations reset	Position sensor calibration	Torque sensor calibration	System calibration	Replacement of UniAir module	Replacement of timing sensor or cam	UniAir actuator dispersion correction	Replacement of RPM sensor or distribution belt	Replacement of oil temperature sensor
All model		AISIN AF40-6 Automatic Gearbox	V	V	V	V	V			V																													
		Marelli SELESPEED CFC228F Automatic Gearbox	V	V	V	V	V																																
		Basic system	V	V			V																																
		Basic system	V	V			V																																
	ABS	TRW Lucas ABS(ESP)	V	V	V	V	V											V				V	V	V	V														
		Bosch ABS 5.7 VDC	V	V	V	V	V											V																					
		Bosch ABS 8 VDC	V	V	V	V	V											V				V																	
		Bosch ABS 5.7 ASR/TC	V	V	V	V	V																																
		Bosch ABS 8	V	V	V	V	V																																
		Bosch ABS 8 ESP	V	V	V	V	V															V																	
		Bosch ABS 9 ESP	V	V	V	V	V																																
		Continental MK60EC ABS	V	V	V	V	V												V	V	V				V														
		Bosch ABS 8 ESP (2)	V	V	V	V	V															V																	
		ABS Teves MK20/MK70	V	V	V	V	V																																
		Basic system	V	V			V																																
		Basic system	V	V			V																																
	Power steering	Delphi Electric Steering (2)	V	V	V	V	V																									V	V						
		Delphi Electric Steering	V	V	V	V	V																									V	V						
		Delphi Electric Steering MY12	V	V	V		V																									V	V						
		ZF Electric Steering	V	V	V	V	V																									V							
		Delphi Electric Steering I	V	V	V		V																									V	V						
		Delphi Electric Steering II	V	V	V	V	V																								V	V	V	V					
		Basic system	V	V			V																																
		Basic system	V	V			V																																
	Airbag	SIEMENS MY06 Airbag (Ep - PROXI)	V	V	V	V	V																																
		AUTOLIV MY07 Airbag (Ep - PROXI)	V	V	V	V	V																																
		CONTINENTAL Airbag (Ep - PROXI)	V	V	V	V	V																																
		BOSCH Airbag (Ep - PROXI)	V	V	V	V	V																																
		TRW Airbag (Ep - PROXI)	V	V	V	V	V																																
		TRW MY03 Airbag (2F-2P-2L-2T-1G-I)	V	V	V	V	V																																
		SIEMENS MY06 Airbag	V	V	V	V	V																																
		TRW MY05 Airbag (Ep - PROXI)	V	V	V	V	V																																
		TRW Airbag MY12	V	V	V		V																																
		SIEMENS MY99 Airbag (2F-2P-2L-2T-I)	V	V	V	V	V																																
		TRW MY97 Airbag (2F-2L-I)	V	V	V		V																																
		Autoliv MY99 Airbag (2F-2P-2L-I)	V	V	V	V	V																																
		Basic system	V	V			V																																
		Basic system	V	V			V																																
		Basic system	V	V			V																																
		Type1	V	V	V	V	V				V																												

Model	System	System2	DTC Analysis	DTC Erase	Data Analysis	Actuation Test	ECU Information Display	Flap actuators learning	Vehicle configuration reset	Gearbox lever position learn	Key programming	Remote programming	Engine service reset type#1	Engine service reset type#2	Oil change (only for version with DPF)	Tow hook	Next service reset	Steering angle	Lateral and longitudinal acceleration sensor calibration	Steering angle calibration	Reset steering angle	Longitudinal acceleration sensor calibration	Yaw sensor calibration	Lateral acceleration sensor calibration	Pressure sensor calibration	Power Supply Mode (Logistic Mode)	Indicators command	Power supply mode	Rearm inertia switch(FIS)	Activate seat belt alarm	Torque/position calibrations reset	Position sensor calibration	Torque sensor calibration	System calibration	Replacement of UniAir module	Replacement of timing sensor or cam	UniAir actuator dispersion correction	Replacement of RPM sensor or distribution belt	Replacement of oil temperature sensor
	Immobilizer	Type2	V	V	V	V	V				V																												
		Type3	V	V	V	V	V				V	V																											
	Body	Body Computer Delphi/Marelli	V	V	V	V	V																																
		Body Computer Marelli 1	V	V	V	V	V																																
		Body Computer Marelli 2	V	V	V	V	V																			V													
		Body Computer Siemens	V	V	V	V	V																			V													
		Body Computer Marelli (198)	V	V	V	V	V																			V													
		Body Computer Marelli (188FL) MY03	V	V	V	V	V																																
		Body Computer Marelli (323)	V	V	V	V	V																																
		Body Computer Delphi 1	V	V	V	V	V																					V	V										
		Body Computer Delphi 2	V	V	V	V	V																					V											
		Body Computer Delphi 3	V	V	V	V	V																					V	V										
		Body Computer Marelli(940)	V	V	V	V	V																				V	V	V										
		Basic system	V	V			V																																
		Basic system	V	V			V																																
	Instrument	Instrument Panel Mannesman VDO	V	V	V	V	V										V																						
		Instrument Panel Marelli (Base/Comfort)	V	V	V	V	V										V													V									
		Instrument Panel Marelli	V	V	V	V	V										V													V									
		Instrument Panel Marelli	V	V	V	V	V										V													V									
		Instrument Panel Marelli G1	V	V	V	V	V										V																						
		Instrument Panel Marelli	V	V	V	V	V										V																						
		Instrument Panel Marelli	V	V	V	V	V										V													V									
		Instrument Panel Marelli	V	V	V	V	V										V													V									
		Instrument Panel Marelli II	V	V	V	V	V										V																						
		Instrument Panel Marelli MY12	V	V	V	V	V										V													V									
		Instrument Panel Siemens	V	V	V	V	V										V																						
		Basic system	V	V			V																																
		Basic system	V	V			V																																
	Navigation	Convergence Marelli/Microsoft (Blue&Me)	V	V			V																																
		Basic system	V	V			V																																
		Basic system	V	V			V																																
		Basic system	V	V			V																																
	Climate	Delphi climate control (Dual zone)	V	V	V	V	V																																
		Delphi climate control (Dual/three zone)	V	V	V	V	V																																
		Marelli climate control	V	V	V	V	V	V																															
		Basic system	V	V			V																																
		Basic system	V	V			V																																
		Basic system	V	V			V																																
	Headlamp(Left)	Basic system	V	V			V																																
	Headlamp(Right)	Basic system	V	V			V																																

Model	System	System2	DTC Analysis	DTC Erase	Data Analysis	Actuation Test	ECU Information Display	Flap actuators learning	Vehicle configuration reset	Gearbox lever position learn	Key programming	Remote programming	Engine service reset type#1	Engine service reset type#2	Oil change (only for version with DPF)	Tow hook	Next service reset	Steering angle	Lateral and longitudinal acceleration sensor calibration	Steering angle calibration	Reset steering angle	Longitudinal acceleration sensor calibration	Yaw sensor calibration	Lateral acceleration sensor calibration	Pressure sensor calibration	Power Supply Mode (Logistic Mode)	Indicators command	Power supply mode	Rearm inertia switch(FIS)	Activate seat belt alarm	Torque/position calibrations reset	Position sensor calibration	Torque sensor calibration	System calibration	Replacement of UniAir module	Replacement of timing sensor or cam	UniAir actuator dispersion correction	Replacement of RPM sensor or distribution belt	Replacement of oil temperature sensor
	Driver door	Driver's Door G.E. PROCOND	V	V	V	V	V																																	
		Driver's Door TRW	V	V	V	V	V																																	
		Basic system	V	V			V																																	
	Passenger door	Passenger's Door G.E. PROCOND	V	V	V	V	V																																	
		Basic system	V	V			V																																	
	Parking control	Parking Control VALEO	V	V	V	V	V																																	
		Parking Control VALEO	V	V	V	V	V									V																								
		Basic system	V	V			V																																	
		Basic system	V	V			V																																	
	Boot	Boot TRW	V	V	V	V	V																																	
		Boot G.E. PROCOND	V	V	V	V	V																																	
		Basic system	V	V			V																																	

Model	System	System2	Self-adaptation reset	Phonic wheel learn reset	Reset self-learnt functions	Self-adaptation parameters reset	Throttle position learning	Cam edges reset (VVT)	Neutral signal learn	Oil change	Cruise control re-learn	Oil change (only for version with DPF)	Particle filter replacement (only for version with DPF)	Particle filter regeneration (only for version with DPF)	Injector programming	Zeroing of self-adaption parameters	Replacement of control unit and injectors	Rail pressure sensor replacement	Pre-catalyser replacement (only for version with DPF)	Differential pressure sensor replacement (only for version with DPF)	Lambda sensor replacement (only for version with Lambda sensor)	Air flow meter replacement (only for version with Lambda sensor)	Phonic wheel replacement	Neutral signal learn	Replacement of intelligent alternator (IAM)	Speed limit	Reset self learned value	Accumulator depressurization	Clutch drain	Production/Service final calibration	Clutch self-calibration enable	Clutch degradation index calculation	Actuator base adjustment	Longitudinal acceleration signal learn	Delete statistical data	Delete statistical data related to errors	Clutch replacement	Electropump replacement	Steering wheel levers replacement
Support function	Key programming	Type1																																					
		Type2																																					
		Type3																																					
	Service reset engine	Type1																																					
		Type2																																					
	Service reset instrument	Type1																																					
		Type2																																					
		Type3																																					
		Type4																																					
		Type5																																					
	Engine	Bosch Motronic MeD 7.6.1 CF4/EOBD Injection(1.9, 2.2)	V																																				
		Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	V	V																																			
		Bosch EDC16C39 CF4/EOBD Diesel Injection (2.3, 3.0)			V							V	V	V	V																								
		Marelli 6F3 EOBD Diesel Injection (1.3)	V									V	V	V	V	V																							
		Bosch Motronic Me7.3.1 EOBD Injection	V																																				
		Bosch EDC15C7 CF3/EOBD Diesel Injection (1.9, 2.4)									V				V																								
		Bosch EDC16C39 CF4/EOBD Diesel Injection (1.9, 2.4)			V							V	V	V	V			V	V	V	V	V																	
		Bosch Motronic MED7.11 EOBD Injection	V																																				
		Magneti Marelli IAW 5NF EOBD Injection	V	V																																			
		Bosch Motronic Me7.9.10 CF5/EOBD Injection (1.4)			V	V																		V															
		Delphi MT27E Injection (1.8)	V																																				
		Magneti Marelli IAW 4SF Injection	V	V																																			
		Magneti Marelli IAW 5SF CF4/EOBD Injection (1.4 8V)	V	V																																			
		Magneti Marelli IAW 5SF8 CF5/EOBD Injection (8V)		V	V	V	V	V	V																														
		Marelli 6F3 EOBD Diesel Injection		V	V							V	V	V	V		V	V	V	V	V	V																	
		Bosch Motronic MeD17.3.1 CF5/EOBD Injection (1.8)			V	V				V																													
		Marelli 8F3 CF5/EOBD Diesel Injection (1.3)			V							V	V	V	V		V	V	V	V	V	V	V	V	V	V													
		Magneti Marelli IAW 5SF3 CF4/EOBD Injection (8V)		V	V	V	V																																
		Marelli 8DF CF5/EOBD Diesel Injection (1.3)		V	V							V	V	V	V		V	V		V	V	V		V															
		Magneti Marelli IAW 8GMF CF5/EOBD Injection (1.4 16V)	V	V		V	V		V	V															V														
		Bosch EDC17CP52 CF5/EOBD Diesel Injection (3.0)			V								V	V	V		V	V		V	V	V																	
		Magneti Marelli IAW 8GMW CF5/EOBD Injection (1.4)	V	V		V	V		V	V															V														
		Basic system																																					
		Basic system																																					
		Basic system																																					
	AT	Marelli selespeed CFC300																									V	V	V	V	V		V		V		V	V	V
		Marelli SELESPEED CFC348 Automatic Gearbox																									V	V	V	V	V		V	V	V		V	V	
		Marelli SELESPEED CFC218F GTA Automatic Gearbox																										V	V	V	V	V	V		V		V	V	V
		Marelli SELESPEED CFC300 Automatic Gearbox																									V	V	V	V	V		V		V		V	V	V
		Marelli SELESPEED CFC328 Automatic Gearbox																									V	V	V	V	V		V	V	V		V	V	V

Model	System	System2	Self-adaptation reset	Phonic wheel learn reset	Reset self-learnt functions	Self-adaptation parameters reset	Throttle position learning	Cam edges reset (VVT)	Neutral signal learn	Oil change	Cruise control re-learn	Oil change (only for version with DPF)	Particle filter replacement (only for version with DPF)	Particle filter regeneration (only for version with DPF)	Injector programming	Zeroing of self-adaption parameters	Replacement of control unit and injectors	Rail pressure sensor replacement	Pre-catalyser replacement (only for version with DPF)	Differential pressure sensor replacement (only for version with DPF)	Lambda sensor replacement (only for version with Lambda sensor)	Air flow meter replacement (only for version with Lambda sensor)	Phonic wheel replacement	Neutral signal learn	Replacement of intelligent alternator (IAM)	Speed limit	Reset self learned value	Accumulator depressurization	Clutch drain	Production/Service final calibration	Clutch self-calibration enable	Clutch degradation index calculation	Actuator base adjustment	Longitudinal acceleration signal learn	Delete statistical data	Delete statistical data related to errors	Clutch replacement	Electropump replacement	Steering wheel levers replacement
All model		AISIN AF40-6 Automatic Gearbox	V																																				
		Marelli SELESPEED CFC228F Automatic Gearbox			V																							V	V	V	V	V	V		V	V	V	V	V
		Basic system																																					
		Basic system																																					
	ABS	TRW Lucas ABS(ESP)																																					
		Bosch ABS 5.7 VDC																																					
		Bosch ABS 8 VDC																																					
		Bosch ABS 5.7 ASR/TC																																					
		Bosch ABS 8																																					
		Bosch ABS 8 ESP																																					
		Bosch ABS 9 ESP																																					
		Continental MK60EC ABS																																					
		Bosch ABS 8 ESP (2)																																					
		ABS Teves MK20/MK70																																					
		Basic system																																					
		Basic system																																					
	Power steering	Delphi Electric Steering (2)																																					
		Delphi Electric Steering																																					
		Delphi Electric Steering MY12																																					
		ZF Electric Steering																																					
		Delphi Electric Steering I																																					
		Delphi Electric Steering II																																					
		Basic system																																					
		Basic system																																					
	Airbag	SIEMENS MY06 Airbag (Ep - PROXI)																																					
		AUTOLIV MY07 Airbag (Ep - PROXI)																																					
		CONTINENTAL Airbag (Ep - PROXI)																																					
		BOSCH Airbag (Ep - PROXI)																																					
		TRW Airbag (Ep - PROXI)																																					
		TRW MY03 Airbag (2F-2P-2L-2T-1G-I)																																					
		SIEMENS MY06 Airbag																																					
		TRW MY05 Airbag (Ep - PROXI)																																					
		TRW Airbag MY12																																					
		SIEMENS MY99 Airbag (2F-2P-2L-2T-I)																																					
		TRW MY97 Airbag (2F-2L-I)																																					
		Autoliv MY99 Airbag (2F-2P-2L-I)																																					
		Basic system																																					
		Basic system																																					
		Basic system																																					
		Type1																																					

Model	System	System2	Self-adaptation reset	Phonic wheel learn reset	Reset self-learnt functions	Self-adaptation parameters reset	Throttle position learning	Cam edges reset (VVT)	Neutral signal learn	Oil change	Cruise control re-learn	Oil change (only for version with DPF)	Particle filter replacement (only for version with DPF)	Particle filter regeneration (only for version with DPF)	Injector programming	Zeroing of self-adaption parameters	Replacement of control unit and injectors	Rail pressure sensor replacement	Pre-catalyser replacement (only for version with DPF)	Differential pressure sensor replacement (only for version with DPF)	Lambda sensor replacement (only for version with Lambda sensor)	Air flow meter replacement (only for version with Lambda sensor)	Phonic wheel replacement	Neutral signal learn	Replacement of intelligent alternator (IAM)	Speed limit	Reset self learned value	Accumulator depressurization	Clutch drain	Production/Service final calibration	Clutch self-calibration enable	Clutch degradation index calculation	Actuator base adjustment	Longitudinal acceleration signal learn	Delete statistical data	Delete statistical data related to errors	Clutch replacement	Electropump replacement	Steering wheel levers replacement
	Immobilizer	Type2																																					
		Type3																																					
	Body	Body Computer Delphi/Marelli																																					
		Body Computer Marelli 1																																					
		Body Computer Marelli 2																																					
		Body Computer Siemens																																					
		Body Computer Marelli (198)																																					
		Body Computer Marelli (188FL) MY03																																					
		Body Computer Marelli (323)																																					
		Body Computer Delphi 1																																					
		Body Computer Delphi 2																																					
		Body Computer Delphi 3																																					
		Body Computer Marelli(940)																																					
		Basic system																																					
		Basic system																																					
	Instrument	Instrument Panel Mannesman VDO																																					
		Instrument Panel Marelli (Base/Comfort)																																					
		Instrument Panel Marelli																																					
		Instrument Panel Marelli																																					
		Instrument Panel Marelli G1																																					
		Instrument Panel Marelli																																					
		Instrument Panel Marelli																																					
		Instrument Panel Marelli																																					
		Instrument Panel Marelli II																																					
		Instrument Panel Marelli MY12																																					
		Instrument Panel Siemens																																					
		Basic system																																					
		Basic system																																					
	Navigation	Convergence Marelli/Microsoft (Blue&Me)																																					
		Basic system																																					
		Basic system																																					
		Basic system																																					
	Climate	Delphi climate control (Dual zone)																																					
		Delphi climate control (Dual/three zone)																																					
		Marelli climate control																																					
		Basic system																																					
		Basic system																																					
		Basic system																																					
	Headlamp(Left)	Basic system																																					
	Headlamp(Right)	Basic system																																					

Model	System	System2	Self-adaptation reset	Phonic wheel learn reset	Reset self-learnt functions	Self-adaptation parameters reset	Throttle position learning	Cam edges reset (VVT)	Neutral signal learn	Oil change	Cruise control re-learn	Oil change (only for version with DPF)	Particle filter replacement (only for version with DPF)	Particle filter regeneration (only for version with DPF)	Injector programming	Zeroing of self-adaption parameters	Replacement of control unit and injectors	Rail pressure sensor replacement	Pre-catalyser replacement (only for version with DPF)	Differential pressure sensor replacement (only for version with DPF)	Lambda sensor replacement (only for version with Lambda sensor)	Air flow meter replacement (only for version with Lambda sensor)	Phonic wheel replacement	Neutral signal learn	Replacement of intelligent alternator (IAM)	Speed limit	Reset self learned value	Accumulator depressurization	Clutch drain	Production/Service final calibration	Clutch self-calibration enable	Clutch degradation index calculation	Actuator base adjustment	Longitudinal acceleration signal learn	Delete statistical data	Delete statistical data related to errors	Clutch replacement	Electropump replacement	Steering wheel levers replacement
	Driver door	Driver's Door G.E. PROCOND																																					
		Driver's Door TRW																																					
		Basic system																																					
	Passenger door	Passenger's Door G.E. PROCOND																																					
		Basic system																																					
	Parking control	Parking Control VALEO																																					
		Parking Control VALEO																																					
		Basic system																																					
		Basic system																																					
	Boot	Boot TRW																																					
		Boot G.E. PROCOND																																					
		Basic system																																					

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Values | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase/Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(Beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase/Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the water in fuel Warning Indicator | Reset the Powertrain Control Module Learned Vaus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(Beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the water in fuel Warning Indicator | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(Beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(Beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase/Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(Beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAV ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Hall Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase/Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(Beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase/Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAV ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC EraseMemory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase/Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuraton | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset The Exhaust Gas Temperature Value | Reset The High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAV ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Vaus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase/Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the water in fuel Warning Indicator | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | MAF sensor reset | PCM reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC EraseMemory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuraton | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the water in fuel Warning Indicator | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase/Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the water in fuel Warning Indicator | Reset the Powertrain Control Module Learned Vaus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC EraseMemory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the water in fuel Warning Indicator | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuraton | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(Beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAV ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(Beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Hall Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase/Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase/Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase/Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Valus | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC Erase/Memory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the Powertrain Control Module Learned Values | Reset the Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test Type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | DTC Analysis | DTC EraseMemory | Data Analysis | Actuation Test | ECU Information Display | Incode calculator | Reset KAM | Key on engine off self test | Key on engine run self test | Power balance | ON-Demand Self test | Steering Angle Sensor Calibration | ABS Service Bleed | Module Installation | Lateral acceleration sensor initialization | Longitudinal acceleration sensor initialization | Steering angle sensor initialization | Keyfob training | Erase and program keys | Parameter reset | Audio Speaker Walkaround Test | Parameter reset(LPG) | Body type | Exterior lighting | Climate control | Personality | Calibration | Audio configuration | ABS service bleed | Key On Engine Off Self Test | PCM Parameter reset | Fuel Injector correction factors | DPF Static Regeneration | Reset the Intake Air Throttle Valve Learned Values | Reset the Exhaust Gas Recirculation Valve Learned Values | Reset the Diesel Particulate Filter Learned Values | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | Reset the water in fuel Warning Indicator | Reset the Powertrain Control Module Learned Valus | Reset The Exhaust Gas Temperature Value | Reset the High Pressure Fuel System Learned Values | Reset the Mass Air Flow Sensor Learned Values | Reset the Fuel Injector Learned Values | Reset the Turbocharger Learned Values | Stop-Start Activation | Key On Engine Run Self Test | Ignition key code erase and program | Program additional ignition key | Steering angle sensor | Lateral Acceleration Sensor/Longitudinal Acceleration Sensor | Battery monitoring system reset | RCM Module Installation | TBM SIM RAY ID | Reset TBM Password | ACM Module Installation | MAF Correction | PCM reset | MAF sensor reset | Fuel System Vaporizer Prime | Ambient Air Temp Sensor Configuration | Battery monitoring system reset(beta) | Clear Transmission Adaptive Tables | Stop Use of Transmission Adaptive | Halt Transmission Adaptive Learning | Resume Transmission Adaptive Learning | TR Sensor Test type | IVD Initialization Sequence | ABS Installation | Tones Test | IC Module Installation | Factory Keyless Entry Code |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Mistire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key programming | Ignition key erase | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key programming | Ignition key erase | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger Zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key programming | Ignition key erase | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | KVC Configuration Test | Passenger System Reset | Passenger Zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display Test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | TC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key programming | Ignition key erase | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger Zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key programming | Ignition key erase | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Mistire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization-Test | RVC Configuration-Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation-Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization-Test | RVC Configuration-Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation-Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger Zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display Test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | KVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module initialization | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization-Test | RVC Configuration-Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation-Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | TC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Mistire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keytobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization-Test | RVC Configuration-Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation-Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | TC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | TC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keytops | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | TC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | TC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Visual Leak Check | SCR Parameter Reset | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | TC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Emptying | SCR System Refill Activation | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | TC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization-Test | RVC Configuration-Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation-Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEL Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | TC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEI Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization-Test | RVC Configuration-Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation-Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module initialization | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEL Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PTC Reset | ABS Module Installation | Infotainment Display test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | IC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/Clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key erase | Ignition key programming | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module Initialization | Bleed-Brake Caliper | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | View Current Remote Trasmitter TIC | View Programmed Keyfobs | Reprogram a new Remote Transmitter | Misfire Monitor Neutral Profile Correction | Relearn Vehicle Data | Rear Tones Test | CEL Lock Configuration | BMS Reset | Remote Keyless Entry Code | LIN New Module Initialization Test | RVC Configuration Test | Passenger System Reset | Passenger zero Seat Weight Test | PDC Reset | ABS Module Installation | Infotainment Display Test | DCSM Module Installation Test | FDIM Module Installation | HVAC Module Installation | Reset KAM TCM | TR Sensor Test | Erase One Remote Transmitter | Erase All Remote Transmitter | Injector electrical test | Engine running test | Injector contribution test | Yaw Rate Sensor | Ignition key code erase | TC Installation | PATS Function | DPF Reset | Clear EGR Adaptive Tables | Clear Fuel Injector/HP Pump Adaptive Tables | Water in Fuel Reset | DPF Manual Regeneration | Reset/clear Specified Function | Injector Quantity Adjustment | SCR System Refill Activation | SCR System Emptying | SCR Parameter Reset | SCR Visual Leak Check | SCR Dosing Measurement Test | DPF Parameter Reset | DPF Regeneration Suspension | LIN New Module Initialization | Reset the Powertrain Control Module Learned Values | Ignition key programming | Ignition key erase | Reset transmission table | Reset learned values | IVD initialization sequence | Configure the lateral acceleration sensor | Configure the longitudinal acceleration sensor | Configure the pressure sensor | Configure the yaw rate sensor | Module initialization | Bleed-Drum Brake-Wheel Cylinder | Bleed-Brake Hose | Bleed-Brake Tubes | Bleed-Brake Master Cylinder | Bleed-ABS module | Bleed-Brake Fluid Change | Rear Brake Adjustment | Calibration steering angle sensor | Configure the steering column assembly | Configure the Intermediate Shaft | Pull Drift Compensation | Parameter Reset Clear Crash Data Memory | Remote Keyless Entry | ABS Service Bleed(ABS) |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMII Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New PACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID Test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | HIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Accelerometer Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Ahead Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCM Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New PCM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password test | TBM Transit Mode test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCM Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New PCM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMII Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Ahead Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID Test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | HIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMII Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New PCM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New PCM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password test | TBM Transit Mode test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMII Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID Test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID Test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMII Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM (Fuel Additive Control Module) | Refill the FAT (Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMII Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | HIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCM Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | HIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Accelerometer Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | IBM SIM RAV ID Test | Reset IBM Password Test | IBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Ahead Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | IBM SIM RAV ID-Test | Reset IBM Password-Test | IBM Transit Mode-Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | HM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Headlamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID Test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | HIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New PCM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password test | TBM Transit Mode test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | HIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Ahead Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New PCM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password test | TBM Transit Mode test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil Change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | HIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Headlamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New PCM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV_ID test | Reset TBM Password test | TBM Transit Mode test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID-Test | Reset TBM Password-Test | TBM Transit Mode-Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil Change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password test | TBM Transit Mode test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID Test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCM Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New PCM(Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password test | TBM Transit Mode test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCM Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID Test | TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCM Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMII Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID Test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMii Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Head Lamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New FACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID test | TBM Password test | Reset TBM Transit Mode test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | FIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning indicator | Reset the Knock Sensor Learned Values | Reset the Fuel Metering Valve Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | ABS Service Bleed(ABS/ESP) | Configure the lateral acceleration sensor | Configure the steering angle sensor | ABS Module Initialization | Prime the fuel system | Wiper Motor Module Calibration | CCMII Sensor Alignment | Driver Window Motor Test | Power Window Initialization Driver Side | Headlamp Alignment | Passenger Window Motor Test | Power Window Initialization Passenger Side | Steering Angle Adaption Angle Reset | Pull Drift Compensation Enable/Disable | RCM Configuration | Ignition keys erase | Ignition keys program | Configure pressure sensor | Configure Yaw rate and Lateral acceleration sensors | Configure longitudinal acceleration sensor | Fuel Injector Correction Factors | Reset the EGR Valve Learned Values | Reset the DPF learned values | Reset the DPF differential pressure sensor learned value | Diesel Particulate Filter Static Regeneration | Auxiliary vehicle ID reset | ABS/EPS Service Bleed | Module Reset | New PACM Fuel Additive Control Module) | Refill the FAT(Fuel Additive Tank) | TBM SIM RAV ID Test | Reset TBM Password Test | TBM Transit Mode Test | Ignitions keys erase and reprogram | Additional ignition keys | Remote programming mode | Ignition key code erase and program(Beta) | Program additional ignition key(Beta) | Reset the oil change indicator | Erase and Program keys | ABS reset and configuration | Lateral Acceleration Sensor | Longitudinal Acceleration Sensor | Steering Wheel Position Calibration | BEM Module Installation | HIM Module Installation | ACM Calibration | Brake Fluid Pressure Sensor | Battery Monitoring System Reset | Wiper Motor Module Calibration | TPMS Sensor Training Mode | Steering Wheel Position Sensor Calibration | Reset KAM(Keep Alive Memory) | Reset the DPF Learned Values | Reset Differential Pressure Sensor Learned Values | Reset the Water in Fuel Warning Indicator | Reset the Fuel Metering Valve Learned Values | Reset the Knock Sensor Learned Values | Reset the water in fuel warning indicator | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values | Powertrain Control Module Central Car Configuration Update | ABS/ESP Service Bleed | ESP Configure All Three sensros Togethers. | ESP Configure the pressure sensor | ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors | ESP Calibrate Longitudinal Acceleration Sensor | ESP Inhibit longitudical Accelerometer Monitoring | Reset the Fuel Injector Learned Values-Cylinder 1 | Reset the Fuel Injector Learned Values-Cylinder 2 | Reset the Fuel Injector Learned Values-Cylinder 3 | Reset the Fuel Injector Learned Values-Cylinder 4 |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCM | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCM Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The installation of a new automatic transmission with a new TCM | The Removal and Installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aptm | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Head Lamp Alignment | Module Configuration | Belltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aqum | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCM/ | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection timing learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCM Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The installation of a new AT with a new TCM | The Removal and installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Head Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test apim | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMI | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMII Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test alpm | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMII | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection timing learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMII Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The installation of a new automatic transmission with a new TCM | The Removal and installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aqum | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aqum | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection timing learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and Installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test abnm | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMII | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection timing learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMII Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and Installation of Selector lever | The installation of a new with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aqum | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and Installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Head Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aptm | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCM | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMII Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test adjum | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMI | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMII Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new automatic transmission with a new TCM | The installation of a new AT | The Removal and Installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test adjum | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCM/ | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCM/ Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The installation of a new AT with a new TCM | The Removal and installation of Selector lever | The installation of a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Belltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test alpm | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new automatic transmission with a new TCM | The installation of a new AT | The Removal and installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Head Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test apim | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMII | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMII Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and Installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster Serial Number | Head Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aptm | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The installation of a new automatic transmission with a new TCM | The Removal and Installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster Serial Number | Head Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test adjum | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Inclination Sensor Calibration | Assembly Check | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and Installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aqum | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The installation of a new AT with a new TCM | The Removal and Installation of Selector lever | The installation of a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test apim | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection timing learn | DPF Leg regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aqum | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The installation of a new automatic transmission with a new TCM | The Removal and Installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster Serial Number | Read Lamp Alignment | Module Configuration | Belt minder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test adjum | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and Installation of Selector lever | The installation of a new with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster Serial Number | Head Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test alpm | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Leaneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The installation of a new Automatic transmission with a new TCM | The Removal and installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aqum | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCM | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMII Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aptm | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCM/ | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCM/ Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new automatic transmission with a new TCM | The installation of a new AT | The Removal and Installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Head Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aptm | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCM | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMII Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The installation of a new automatic transmission with a new TCM | The Removal and Installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster Serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test apim | Calibrate Steering Angle Sensor(EPs) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Leaneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The Removal and installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling FAN Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test apim | Calibrate Steering Angle Sensor(EPs) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCMii | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF Regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMii Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new AT | The installation of a new automatic transmission with a new TCM | The Removal and installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster Serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test aptm | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

| Model 1 | Model 2 | System 1 | System 2 | System 3 | Parameter Reset/Configuration BCM | Pull Drift Compensation Reset | Parameter Reset/Configuration Emergency Assist Activation | Injector programming | Depressurize ASM system | Shift actuator bleed | Learn transmission | Learn Clutch Parameter | Learn clutch touch point | Reset the Power Train Control Module Learned Values | Reset the Vehicle Speed Limit | Reset pressure sensor offset | Calibration longitudinal acceleration sensor | Fuel injector pilot correction learn | Fuel injection pump learn | DPF regeneration | Reset the exhaust gas temperature value | Reset the fuel pressure relief valve open count learned value | Reset the fuel pressure relief valve open duration learned value | RCM configuration(Beta) | Ignition key erase | Ignition key program | Pressure Sensor Calibration | Prime the Fuel System | CAR Mod(Normal) | CAR Mod(Transport) | TPMS Sensor Learn Routine | BCMII Crash Reset | Driver's Seat Module | EPB Parameter Reset/Configuration | Assembly Check | Inclination Sensor Calibration | Maintenance Mode | Static Apply | Clear Stored Clutch Engagement Point | Module Configuration | RCM Parameter reset / configuration | Reset the Turbocharger Variable Vane Position Sensor Learned Values | Enter the Fuel Injector Default Count Value | TPMS Drive the Vehicle | SOD-L Module Reset | SOD-R Module Reset | Shift fork system learn | Configuration the yaw rate sensor | Module Configuration | RCM Parameter Reset/Configuration | The Installation of a new Automatic Transmission with the original TCM | The Removal and installation of Selector lever or the Selector lever Cable | Transmission Fluid Drain and Refill | The Installation of a new TCM | The installation of a new automatic transmission with a new TCM | The installation of a new AT | The Removal and Installation of Selector lever | The installation of a new AT with a new TCM | Reset the Diesel Particulate Filter Learned Values | Read the Sensor Cluster serial Number | Read Lamp Alignment | Module Configuration | Beltminder Enable/Disable | Injector Correction Factors | Reset Charge Air Cooler Bypass Valve Position Offset | Reset the Cooling Fan Motor Learned Values | Reset Charge Air Cooler Bypass Valve Position Offset | Reset Transmission Tables | Ignition Key Erase | Ignition Key Programming | Key On Engine Off Self Test &pm | Calibrate Steering Angle Sensor(EPS) | Program additional Ignition Key | Ignition Key Code Erase and Program |
|---|---|---

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
Incode Calculator	~2010.05	All model								
FALCON	FGX	PCM(PowerTrain Control Module)								
FALCON	FGX	TCM(Transmission Control Module)								
FALCON	FGX	ABS(Anti-Lock Brake System)								
FALCON	FGX	RCM(Restraint Control Module)								
FALCON	FGX	BEM(Body Electronic Module)								
FALCON	FGX	IC(Instrument Cluster)								
FALCON	FGX	HIM(HVAC Integrated Module)								
FALCON	FGX	FCIM(Front Controls Interface Module)								
FALCON	FGX	APIM(Accessory Protocol Interface Module)								
FALCON	FGX	GPSM(Global Positioning System Module)								
FALCON	FGX	GWM(Gateway Module A)								
FALCON	FGX	PAM(Park Aid Module)								
FALCON	FGX	ACM(Audio Control Module)								
FALCON	FG	PCM(PowerTrain Control Module)								
FALCON	FG	Incode calculator								
FALCON	FG	TCM(Transmission Control Module)								
FALCON	FG	ABS(Anti-Lock Brake System)								
FALCON	FG	RCM(Restraint Control Module)								
FALCON	FG	BEM(Body Electronic Module)								
FALCON	FG	IC(Instrument Cluster)								
FALCON	FG	FDIM(Front Display Interface Moudle)								
FALCON	FG	HIM(HVAC Integrated Module)								
FALCON	FG	ACM(Audio Control Module)								
FALCON	FG	PAM(Park Aid Module)								
FALCON	FG	AIM(Audio Interface Module)								
FALCON	FG	BPM(Bluetooth Phone Module)								
FALCON	BF	PCM(PowerTrain Control Module)								
FALCON	BF	TCM(Transmission Control Module)								
FALCON	BF	ABS(Anti-Lock Brake System)								
FALCON	BF	RCM(Restraint Control Module)								
FALCON	BF	BEM(Body Electronic Module)								
FALCON	BF	IC(Instrument Cluster)								
FALCON	BF	HIM(HVAC Integrated Module)								
FALCON	BF	ACM(Audio Control Module)								
FALCON	BF	PAM(Park Aid Module)								
FALCON	BA	PCM(PowerTrain Control Module)								
FALCON	BA	ABS(Anti-Lock Brake System)								
FALCON	BA	RCM(Restraint Control Module)								
FALCON	BA	BEM(Body Electronic Module)								
FALCON	BA	IC(Instrument Cluster)								
FALCON	BA	HIM(HVAC Integrated Module)								
FALCON	BA	ACM(Audio Control Module)								
FALCON	BA	PAM(Park Aid Module)								
FALCON	AU III	PCM(PowerTrain Control Module)								
FALCON	AU III	ABS(Anti-Lock Brake System)	ABS(With Traction)							
FALCON	AU III	ABS(Anti-Lock Brake System)	ABS(Without Traction)							
FALCON	AU III	RCM(Restraint Control Module)								
FALCON	AU III	BEM(Body Electronic Module)								
FALCON	AU III	IC(Instrument Cluster)								
FALCON	AU III	ACM(Audio Control Module)								
FALCON	AU II FORTE	PCM(PowerTrain Control Module)								
FALCON	AU II FORTE	ABS(Anti-Lock Brake System)	ABS(With Traction)							
FALCON	AU II FORTE	ABS(Anti-Lock Brake System)	ABS(Without Traction)							
FALCON	AU II FORTE	RCM(Restraint Control Module)								
FALCON	AU II FORTE	BEM(Body Electronic Module)								
FALCON	AU II FORTE	IC(Instrument Cluster)								
FALCON	AU II FORTE	ACM(Audio Control Module)								
FALCON	AU II FUTURA	PCM(PowerTrain Control Module)								
FALCON	AU II FUTURA	ABS(Anti-Lock Brake System)	ABS(With Traction)							
FALCON	AU II FUTURA	ABS(Anti-Lock Brake System)	ABS(Without Traction)							
FALCON	AU II FUTURA	RCM(Restraint Control Module)								
FALCON	AU II FUTURA	BEM(Body Electronic Module)								
FALCON	AU II FUTURA	IC(Instrument Cluster)								
FALCON	AU II FUTURA	ACM(Audio Control Module)								
FALCON	AU II XR	PCM(PowerTrain Control Module)								
FALCON	AU II XR	ABS(Anti-Lock Brake System)	ABS(With Traction)							
FALCON	AU II XR	ABS(Anti-Lock Brake System)	ABS(Without Traction)							
FALCON	AU II XR	RCM(Restraint Control Module)								

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FALCON	AU II XR	BEM(Body Electronic Module)								
FALCON	AU II XR	IC(Instrument Cluster)								
FALCON	AU II XR	ACM(Audio Control Module)								
FALCON	AU FORTE	PCM(PowerTrain Control Module)								
FALCON	AU FORTE	ABS(Anti-Lock Brake System)	ABS(With Traction)							
FALCON	AU FORTE	ABS(Anti-Lock Brake System)	ABS(Without Traction)							
FALCON	AU FORTE	RCM(Restraint Control Module)								
FALCON	AU FORTE	BEM(Body Electronic Module)	BEM(With Smartshield)							
FALCON	AU FORTE	BEM(Body Electronic Module)	BEM(Without Smartshield)							
FALCON	AU FORTE	IC(Instrument Cluster)								
FALCON	AU FUTURA	PCM(PowerTrain Control Module)								
FALCON	AU FUTURA	ABS(Anti-Lock Brake System)	ABS(With Traction)							
FALCON	AU FUTURA	ABS(Anti-Lock Brake System)	ABS(Without Traction)							
FALCON	AU FUTURA	RCM(Restraint Control Module)								
FALCON	AU FUTURA	BEM(Body Electronic Module)	BEM(With Smartshield)							
FALCON	AU FUTURA	BEM(Body Electronic Module)	BEM(Without Smartshield)							
FALCON	AU FUTURA	IC(Instrument Cluster)								
RANGER(BT-50)	2.2 Diesel(Beta)	PCM(PowerTrain Control Module)								
RANGER(BT-50)	2.2 Diesel(Beta)	TCM(Transmission Control Module)								
RANGER(BT-50)	2.2 Diesel(Beta)	PATS(Passive anti theft system)								
RANGER(BT-50)	2.2 Diesel(Beta)	ABS(Anti-Lock Brake System)								
RANGER(BT-50)	2.2 Diesel(Beta)	BCMii(Body Control Module)								
RANGER(BT-50)	2.2 Diesel(Beta)	RCM(Restraint Control Module)								
RANGER(BT-50)	2.2 Diesel(Beta)	IPC(Instrument Panel Control Module)								
RANGER(BT-50)	2.2 Diesel(Beta)	HVAC(Heating Ventilation Air Conditioning)								
RANGER(BT-50)	2.2 Diesel(Beta)	DDM(Drivers Door Module)								
RANGER(BT-50)	2.2 Diesel(Beta)	PDM(Passengers Door Module)								
RANGER(BT-50)	2.2 Diesel(Beta)	PAM(Parking Aid Module)								
RANGER(BT-50)	2.2 Diesel(Beta)	SRM(Speech Recognition Module)								
RANGER(BT-50)	2.2 Diesel(Beta)	TBM(Tracking And Blocking Module)								
RANGER(BT-50)	2.2 Diesel(Beta)	TRM(Trailer Module)								
RANGER(BT-50)	2.2 Diesel(Beta)	FCDIM(Front Control/Display Interface Module)								
RANGER(BT-50)	2.2 Diesel(Beta)	ACM(Audio Control Module)								
RANGER(BT-50)	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)								
RANGER(BT-50)	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)								
RANGER(BT-50)	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)								
RANGER(BT-50)	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)								
RANGER(BT-50)	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)								
RANGER(BT-50)	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)								
RANGER(BT-50)	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)								
RANGER(BT-50)	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)								
RANGER(BT-50)	3.2 Diesel	PCM(PowerTrain Control Module)								
RANGER(BT-50)	3.2 Diesel	TCM(Transmission Control Module)								
RANGER(BT-50)	3.2 Diesel	PATS(Passive anti theft system)								
RANGER(BT-50)	3.2 Diesel	ABS(Anti-Lock Brake System)								
RANGER(BT-50)	3.2 Diesel	BCMii(Body Control Module)								
RANGER(BT-50)	3.2 Diesel	RCM(Restraint Control Module)								
RANGER(BT-50)	3.2 Diesel	IPC(Instrument Panel Control Module)								
RANGER(BT-50)	3.2 Diesel	HVAC(Heating Ventilation Air Conditioning)								
RANGER(BT-50)	3.2 Diesel	DDM(Drivers Door Module)								
RANGER(BT-50)	3.2 Diesel	PDM(Passengers Door Module)								
RANGER(BT-50)	3.2 Diesel	PAM(Parking Aid Module)								
RANGER(BT-50)	3.2 Diesel	SRM(Speech Recognition Module)								
RANGER(BT-50)	3.2 Diesel	TBM(Tracking And Blocking Module)								
RANGER(BT-50)	3.2 Diesel	TRM(Trailer Module)								
RANGER(BT-50)	3.2 Diesel	FCDIM(Front Control/Display Interface Module)								
RANGER(BT-50)	3.2 Diesel	ACM(Audio Control Module)								
E-Series	4.6L(BETA)	2V	PCM(PowerTrain Control Module)							
E-Series	4.6L(BETA)	2V	ABS(Anti-Lock Brake System)							
E-Series	4.6L(BETA)	2V	ACM(Audio Control Module)							
E-Series	4.6L(BETA)	2V	APIM(Accessory Protocol Interface Module)							
E-Series	4.6L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)							
E-Series	4.6L(BETA)	2V	GPSM(Global Positioning System Module)							
E-Series	4.6L(BETA)	2V	IPC(Instrument Panel Control Module)							
E-Series	4.6L(BETA)	2V	PAM(Parking Aid Module)							
E-Series	4.6L(BETA)	2V	RCM(Restraint Control Module)							
E-Series	4.6L(BETA)	2V	SDARS(Satellite Digital Audio Receiver System)							
E-Series	4.6L(BETA)	2V	TBC(Trailer Brake Control Module)							
E-Series	4.6L(BETA)	2V	TCM(Transmission Control Module)							

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
E-Series	5.4L(BETA)	2V	2004 ~	PCM(PowerTrain Control Module)						
E-Series	5.4L(BETA)	2V	2004 ~	ABS(Anti-Lock Brake System)						
E-Series	5.4L(BETA)	2V	2004 ~	IC(Instrument Cluster)						
E-Series	5.4L(BETA)	2V	2004 ~	RAP(Remote Anti-Theft/Personality Module)						
E-Series	5.4L(BETA)	2V	2004 ~	RCM(Restraint Control Module)						
E-Series	5.4L(BETA)	2V	2004 ~	PAM(Parking Aid Module)						
E-Series	5.4L(BETA)	2V	2004 ~	VSM(Vehicle Security Module)						
E-Series	5.4L(BETA)	2V	2009 ~	PCM(PowerTrain Control Module)						
E-Series	5.4L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)						
E-Series	5.4L(BETA)	2V	2009 ~	ACM(Audio Control Module)						
E-Series	5.4L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)						
E-Series	5.4L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)						
E-Series	5.4L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)						
E-Series	5.4L(BETA)	2V	2009 ~	IPC(Instrument Panel Control Module)						
E-Series	5.4L(BETA)	2V	2009 ~	PAM(Parking Aid Module)						
E-Series	5.4L(BETA)	2V	2009 ~	RCM(Restraint Control Module)						
E-Series	5.4L(BETA)	2V	2009 ~	SDARS(Satellite Digital Audio Receiver System)						
E-Series	5.4L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)						
E-Series	5.4L(BETA)	2V	2009 ~	TCM(Transmission Control Module)						
E-Series	6.8L(BETA)	2V	PCM(PowerTrain Control Module)							
E-Series	6.8L(BETA)	2V	ABS(Anti-Lock Brake System)							
E-Series	6.8L(BETA)	2V	ACM(Audio Control Module)							
E-Series	6.8L(BETA)	2V	APIM(Accessory Protocol Interface Module)							
E-Series	6.8L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)							
E-Series	6.8L(BETA)	2V	GPSM(Global Positioning System Module)							
E-Series	6.8L(BETA)	2V	IPC(Instrument Panel Control Module)							
E-Series	6.8L(BETA)	2V	PAM(Parking Aid Module)							
E-Series	6.8L(BETA)	2V	RCM(Restraint Control Module)							
E-Series	6.8L(BETA)	2V	SDARS(Satellite Digital Audio Receiver System)							
E-Series	6.8L(BETA)	2V	TBC(Trailer Brake Control Module)							
E-Series	6.0L(BETA)	Direct Injection - Turbo	PCM(PowerTrain Control Module)							
E-Series	6.0L(BETA)	Direct Injection - Turbo	ABS(Anti-Lock Brake System)							
E-Series	6.0L(BETA)	Direct Injection - Turbo	ACM(Audio Control Module)							
E-Series	6.0L(BETA)	Direct Injection - Turbo	APIM(Accessory Protocol Interface Module)							
E-Series	6.0L(BETA)	Direct Injection - Turbo	GEM/SJB(Generic Electronic Module/Smart Junction Box)							
E-Series	6.0L(BETA)	Direct Injection - Turbo	GPSM(Global Positioning System Module)							
E-Series	6.0L(BETA)	Direct Injection - Turbo	IPC(Instrument Panel Control Module)							
E-Series	6.0L(BETA)	Direct Injection - Turbo	PAM(Parking Aid Module)							
E-Series	6.0L(BETA)	Direct Injection - Turbo	RCM(Restraint Control Module)							
E-Series	6.0L(BETA)	Direct Injection - Turbo	SDARS(Satellite Digital Audio Receiver System)							
E-Series	6.0L(BETA)	Direct Injection - Turbo	TBC(Trailer Brake Control Module)							
E-Series	6.0L(BETA)	Direct Injection - Turbo	TCM(Transmission Control Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)							
F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)							
F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)							
F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)							
F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)							
F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)							

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)							
F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)							
F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)							
F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)							
F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)							
F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)							
F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)							
F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)							
F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)							
F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)							
F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)							
F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)							
F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)							
F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)							
F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)							
F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)							
F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)							
F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)						
F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)						
F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)						
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)						
F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)						
F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)						
F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)						
F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)						
F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)						
F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)						
F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)						
F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)						
F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)						
F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)						
F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)						
F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)						
F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)						
F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)						
F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)						
F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)						
F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)						
F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)						
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)						
F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)						
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)						
F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)						
F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)						
F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)						
F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)						
F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)						
F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)						
F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)						
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)						
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)						
F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)						
F150	4.6L(BETA)	3V		PCM(Powertrain Control Module)						
F150	4.6L(BETA)	3V		ABS(Anti-Lock Brake System)						
F150	4.6L(BETA)	3V		ACM(Audio Control Module)						
F150	4.6L(BETA)	3V		APIM(Accessory Protocol Interface Module)						
F150	4.6L(BETA)	3V		DCSM(Driver-Dual Climate Control Seat Module)						
F150	4.6L(BETA)	3V		DSM(Driver's Seat Module)						
F150	4.6L(BETA)	3V		DSP(Digital Signal Processing Module)						
F150	4.6L(BETA)	3V		FCIM(Front Controls Interface Module)						
F150	4.6L(BETA)	3V		FDIM(Front Display Interface Module)						
F150	4.6L(BETA)	3V		GEM/SJB(Generic Electronic Module/Smart Junction Box)						
F150	4.6L(BETA)	3V		GPSM(Global Positioning System Module)						
F150	4.6L(BETA)	3V		HVAC(Heating Ventilation Air Conditioning)						
F150	4.6L(BETA)	3V		IC(Instrument Cluster)						
F150	4.6L(BETA)	3V		ILCM(Interior Lighting Control Module)						
F150	4.6L(BETA)	3V		OCSM(Occupant Classification System Module)						
F150	4.6L(BETA)	3V		PAM(Parking Aid Module)						
F150	4.6L(BETA)	3V		PRB(Power Running Board)						

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F150	4.6L(BETA)	3V		RCM(Restraint Control Module)						
F150	4.6L(BETA)	3V		TBC(Trailer Brake Control Module)						
F150	4.6L(BETA)	3V		TCCM(Transfer Case Control Module)						
F150	4.6L(BETA)	3V		TCM(Transmission Control Module)						
F150	4.6L(BETA)	3V		TPM(Tire Pressure Monitor)						
F150	5.0L	TiVCT	PCM(Powertrain Control Module)							
F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)							
F150	5.0L	TiVCT	ACM(Audio Control Module)							
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)							
F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)							
F150	5.0L	TiVCT	DSM(Driver's Seat Module)							
F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)							
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)							
F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)							
F150	5.0L	TiVCT	FDIM(Front Display Interface Module)							
F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)							
F150	5.0L	TiVCT	GPSM(Global Positioning System Module)							
F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)							
F150	5.0L	TiVCT	IC(Instrument Cluster)							
F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)							
F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)							
F150	5.0L	TiVCT	PAM(Parking Aid Module)							
F150	5.0L	TiVCT	PRB(Power Running Board)							
F150	5.0L	TiVCT	PSCM(Power Steering Control Module)							
F150	5.0L	TiVCT	RCM(Restraint Control Module)							
F150	5.0L	TiVCT	RTM(Radio Transceiver Module)							
F150	5.0L	TiVCT	SCCM(Steering Column Control Module)							
F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)							
F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)							
F150	5.0L	TiVCT	TCM(Transmission Control Module)							
F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)							
F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)						
F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)						
F150	5.4L	3V	2009 ~	ACM(Audio Control Module)						
F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)						
F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)						
F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)						
F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)						
F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)						
F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)						
F150	5.4L	3V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)						
F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)						
F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)						
F150	5.4L	3V	2009 ~	IC(Instrument Cluster)						
F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)						
F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)						
F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)						
F150	5.4L	3V	2009 ~	PRB(Power Running Board)						
F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)						
F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)						
F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)						
F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)						
F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)						
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)						
F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)						
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)						
F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)						
F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)						
F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)						
F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)						
F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)						
F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)						
F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)						
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)						
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)						
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)						
F150	5.0L	TiVCT	PCM(Powertrain Control Module)							
F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)							
F150	5.0L	TiVCT	ACM(Audio Control Module)							

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)							
F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)							
F150	5.0L	TiVCT	DSM(Driver's Seat Module)							
F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)							
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)							
F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)							
F150	5.0L	TiVCT	FDIM(Front Display Interface Module)							
F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)							
F150	5.0L	TiVCT	GPSM(Global Positioning System Module)							
F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)							
F150	5.0L	TiVCT	IC(Instrument Cluster)							
F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)							
F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)							
F150	5.0L	TiVCT	PAM(Parking Aid Module)							
F150	5.0L	TiVCT	PRB(Power Running Board)							
F150	5.0L	TiVCT	PSCM(Power Steering Control Module)							
F150	5.0L	TiVCT	RCM(Restraint Control Module)							
F150	5.0L	TiVCT	RTM(Radio Transceiver Module)							
F150	5.0L	TiVCT	SCCM(Steering Column Control Module)							
F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)							
F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)							
F150	5.0L	TiVCT	TCM(Transmission Control Module)							
F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)							
F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)							
F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)							
F150	6.2L(BETA)	2V	ACM(Audio Control Module)							
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)							
F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)							
F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)							
F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)							
F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)							
F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)							
F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)							
F150	6.2L(BETA)	2V	IC(Instrument Cluster)							
F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)							
F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)							
F150	6.2L(BETA)	2V	PAM(Parking Aid Module)							
F150	6.2L(BETA)	2V	PRB(Power Running Board)							
F150	6.2L(BETA)	2V	RCM(Restraint Control Module)							
F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)							
F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)							
F150	6.2L(BETA)	2V	TCM(Transmission Control Module)							
F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)							
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)							
F150	Other	2004 ~ 2008	4X4(4x4 Control Module)							
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)							
F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)							
F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)							
F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)							
F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)							
F150	Other	2004 ~ 2008	IC(Instrument Cluster)							
F150	Other	2004 ~ 2008	PAM(Parking Aid Module)							
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)							
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)							
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)							
F250	7.3L	PCM(PowerTrain Control Module)								
F250	7.3L	ABS(Anti-Lock Brake System)								
F250	7.3L	ECS(Electronic Crash Sensor)								
F250	7.3L	GEM(Generic Electronic Module)								
F250	6.2L	PCM(Powertrain Control Module)								
F250	6.2L	ABS(Anti-Lock Brake System)								
F250	6.2L	ACM(Audio Control Module)								
F250	6.2L	APIM(Accessory Protocol Control Module)								
F250	6.2L	BCMii(Body Control Module)								
F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)								
F250	6.2L	DSM(Driver Seat Module)								
F250	6.2L	GPSM(Global Positioning System Module)								
F250	6.2L	HVAC(Heating Ventilation Air Conditioning)								
F250	6.2L	IPC(Instrument Panel Control Module)								

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F250	6.2L	PAM(Parking Aid Module)								
F250	6.2L	RCM(Restraint Control Module)								
F250	6.2L	SCCM(Streering Colume Control Module)								
F250	6.2L	TBC(Trailer Brake Control Module)								
F250	6.2L	TCCM(Transfer Case Control Module)								
F250	6.2L	TPM(Tire Pressure Monitor)								
F250	6.0L	PCM(PowerTrain Control Module)								
F250	6.0L	ABS(Anti-Lock Brake System)								
F250	6.0L	GEM(Generic Electronic Module)								
F250	6.0L	HEC(Hybrid Electrical Cluster)								
F250	6.0L	OTC(Overhead Trip Computer)								
F250	6.0L	PAM(Parking Aid Module)								
F250	6.0L	PATS(Passive Anti Theft System)								
F250	6.0L	RCM(Restraint Control Module)								
F250	6.0L	TCM(Transmission Control Module)								
F250	6.0L	VSM(Vehicle Security Module)								
F-Series Super Duty	5.4L(BETA)	3V	PCM(PowerTrain Control Module)							
F-Series Super Duty	5.4L(BETA)	3V	ABS(Anti-Lock Brake System)							
F-Series Super Duty	5.4L(BETA)	3V	ACM(Audio Control Module)							
F-Series Super Duty	5.4L(BETA)	3V	APIM(Accessory Protocol Interface Module)							
F-Series Super Duty	5.4L(BETA)	3V	DSM(Driver's Seat Module)							
F-Series Super Duty	5.4L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)							
F-Series Super Duty	5.4L(BETA)	3V	GPSM(Global Positioning System Module)							
F-Series Super Duty	5.4L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)							
F-Series Super Duty	5.4L(BETA)	3V	IC(Instrument Cluster)							
F-Series Super Duty	5.4L(BETA)	3V	PAM(Parking Aid Module)							
F-Series Super Duty	5.4L(BETA)	3V	RCM(Restraint Control Module)							
F-Series Super Duty	5.4L(BETA)	3V	RETM(Rear Entertainment Module)							
F-Series Super Duty	5.4L(BETA)	3V	SDARS(Satellite Digital Audio Receiver System)							
F-Series Super Duty	5.4L(BETA)	3V	TBC(Trailer Brake Control Module)							
F-Series Super Duty	5.4L(BETA)	3V	4X4(4x4 Control Module)							
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	2005 ~	PCM(PowerTrain Control Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	2005 ~	ABS(Anti-Lock Brake System)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	2005 ~	EATC(Electronic Automatic Temperature Control)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	2005 ~	GEM(Generic Electronic Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	2005 ~	IC(Instrument Cluster)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	2005 ~	PAM(Parking Aid Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	2005 ~	RCM(Restraint Control Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	2005 ~	TBC(Trailer Brake Control Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	2005 ~	TCM(Transmission Control Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	2005 ~	VSM(Vehicle Security Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	~ 2004	PCM(PowerTrain Control Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	~ 2004	ABS(Anti-Lock Brake System)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	~ 2004	GEM(Generic Electronic Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	~ 2004	HEC(Hybrid Electrical Cluster)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	~ 2004	OTC(Overhead Trip Computer)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	~ 2004	PAM(Parking Aid Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	~ 2004	PATS(Passive Anti Theft System)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	~ 2004	RCM(Restraint Control Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	~ 2004	VSM(Vehicle Security Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	~ 2004	TCM(Transmission Control Module)						
F-Series Super Duty	6.0L Diesel(BETA)	Direct Injection - Turbo	~ 2004	FOH(Fuel Operated Heater)						
F-Series Super Duty	6.2L	2V	PCM(Powertrain Control Module)							
F-Series Super Duty	6.2L	2V	ABS(Anti-Lock Brake System)							
F-Series Super Duty	6.2L	2V	ACM(Audio Control Module)							
F-Series Super Duty	6.2L	2V	APIM(Accessory Protocol Interface Module)							
F-Series Super Duty	6.2L	2V	BCMii(Body control module)							
F-Series Super Duty	6.2L	2V	DCSM(Driver-Dual Climate Control Seat Module)							
F-Series Super Duty	6.2L	2V	DSM(Driver's Seat Module)							
F-Series Super Duty	6.2L	2V	GPSM(Global Positioning System Module)							
F-Series Super Duty	6.2L	2V	HVAC(Heating Ventilation Air Conditioning)							
F-Series Super Duty	6.2L	2V	IPC(Instrument Panel Control Module)							
F-Series Super Duty	6.2L	2V	PAM(Parking Aid Module)							
F-Series Super Duty	6.2L	2V	RCM(Restraint Control Module)							
F-Series Super Duty	6.2L	2V	SCCM(Steering Column Control Module)							
F-Series Super Duty	6.2L	2V	TBC(Trailer Brake Control Module)							
F-Series Super Duty	6.2L	2V	TCCM(Transfer Case Control Module)							
F-Series Super Duty	6.2L	2V	TPM(Tire Pressure Monitor)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	PCM(PowerTrain Control Module)							

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	4X4(4x4 Control Module)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	ABS(Anti-Lock Brake System)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	ACM(Audio Control Module)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	AHCM(Auxiliary Heater Control Module)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	APIM(Accessory Protocol Interface Module)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	CDIM(Circuit Deactivation Ignition Module)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	DSM(Driver's Seat Module)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	GEM/SJB(Generic Electronic Module/Smart Junction Box)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	GPSM(Global Positioning System Module)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	IC(Instrument Cluster)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	PAM(Parking Aid Module)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	RCM(Restraint Control Module)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	RETM(Rear Entertainment Module)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	SDARS(Satellite Digital Audio Receiver System)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	TBC(Trailer Brake Control Module)							
F-Series Super Duty	6.4L Diesel(BETA)	Power Stroke - Direct Injection Turbo Diesel	TCM(Transmission Control Module)							
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	PCM(PowerTrain Control Module)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	ABS(Anti-Lock Brake System)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	ACM(Audio Control Module)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	APIM(Accessory Protocol Interface Module)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	DSM(Driver's Seat Module)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	GPSM(Global Positioning System Module)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	HVAC(Heating Ventilation Air Conditioning)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	IC(Instrument Cluster)						

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	PAM(Parking Aid Module)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	RCM(Restraint Control Module)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	RETM(Rear Entertainment Module)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	SDARS(Satellite Digital Audio Receiver System)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	TBC(Trailer Brake Control Module)						
F-Series Super Duty	6.8L(BETA)	3V	2006 ~	4X4(4x4 Control Module)						
F-Series Super Duty	6.8L(BETA)	3V	~ 2005	PCM(PowerTrain Control Module)						
F-Series Super Duty	6.8L(BETA)	3V	~ 2005	ABS(Anti-Lock Brake System)						
F-Series Super Duty	6.8L(BETA)	3V	~ 2005	EATC(Electronic Automatic Temperature Control)						
F-Series Super Duty	6.8L(BETA)	3V	~ 2005	GEM(Generic Electronic Module)						
F-Series Super Duty	6.8L(BETA)	3V	~ 2005	IC(Instrument Cluster)						
F-Series Super Duty	6.8L(BETA)	3V	~ 2005	PAM(Parking Aid Module)						
F-Series Super Duty	6.8L(BETA)	3V	~ 2005	RCM(Restraint Control Module)						
F-Series Super Duty	6.8L(BETA)	3V	~ 2005	TBC(Trailer Brake Control Module)						
F-Series Super Duty	6.8L(BETA)	3V	~ 2005	VSM(Vehicle Security Module)						
F-Series Super Duty	6.8L(BETA)	3V	~ 2005	TCM(Transmission Control Module)						
FIESTA	1.4L	PCM(PowerTrain Control Module)								
FIESTA	1.4L	PATS(Passive anti theft system)								
FIESTA	1.4L	TCM(Transmission control module)								
FIESTA	1.4L	ABS(Anti-Lock Brake System)								
FIESTA	1.4L	PSCM(Power steering control module)								
FIESTA	1.4L	RCM(Restraint Control Module)								
FIESTA	1.4L	IPC(Instrument panel control)								
FIESTA	1.4L	GEM(Generic Electronic Module)								
FIESTA	1.4L	BCMii(Body control module)								
FIESTA	1.4L	PCDIM(Front interface module)								
FIESTA	1.4L	SRM(Speech recognition module)								
FIESTA	1.4L	ACM(Audio control module)								
FIESTA	1.6L	PCM(PowerTrain Control Module)								
FIESTA	1.6L	PATS(Passive anti theft system)								
FIESTA	1.6L	TCM(Transmission control module)								
FIESTA	1.6L	ABS(Anti-Lock Brake System)								
FIESTA	1.6L	PSCM(Power steering control module)								
FIESTA	1.6L	RCM(Restraint Control Module)								
FIESTA	1.6L	IPC(Instrument panel control)								
FIESTA	1.6L	GEM(Generic Electronic Module)								
FIESTA	1.6L	BCMii(Body control module)								
FIESTA	1.6L	PCDIM(Front interface module)								
FIESTA	1.6L	SRM(Speech recognition module)								
FIESTA	1.6L	ACM(Audio control module)								
FIESTA	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)							
FIESTA	1.8L	ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)							
FIESTA	1.8L	ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)							
FIESTA	1.8L	ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)							
FIESTA	2.0L	PCM(PowerTrain Control Module)								
FIESTA	2.0L	PATS(Passive anti theft system)								
FIESTA	2.0L	ABS(Anti-Lock Brake System)								
FIESTA	2.0L	RCM(Restraint Control Module)								
FIESTA	2.0L	EATC(Electronic Automatic Temperature Control)								
FIESTA	2.0L	IC(Instrument Cluster)								
FIESTA	2.0L	GEM(Generic Electronic Module)								
FIESTA	2.0L	SRM(Speech recognition module)								
FIESTA	2.0L	ACM(Audio control module)								
FOCUS	New Focus 1.6L	PCM(PowerTrain Control Module)								
FOCUS	New Focus 1.6L	PATS(Passive anti theft system)								
FOCUS	New Focus 1.6L	TCM(Transmission Control Module)								
FOCUS	New Focus 1.6L	ABS(Anti-Lock Brake System)								
FOCUS	New Focus 1.6L	ACM(Audio Control Module)								
FOCUS	New Focus 1.6L	AHCM(Auxiliary Heater Control Module)								
FOCUS	New Focus 1.6L	APIM(Accessory Protocol Control Module)								
FOCUS	New Focus 1.6L	BCMii(Body Control Module)								
FOCUS	New Focus 1.6L	CCMii(Cruise Control Module)								
FOCUS	New Focus 1.6L	DDM(Driver's Door Module)								
FOCUS	New Focus 1.6L	DSP(Digital Signal Processing Module)								
FOCUS	New Focus 1.6L	FCIM(Front Controls Interface Module)								
FOCUS	New Focus 1.6L	FDSM								
FOCUS	New Focus 1.6L	FCDIM(Front Control-Display Interface Module)								
FOCUS	New Focus 1.6L	HCM(Headlamp Control Module)								
FOCUS	New Focus 1.6L	HVAC(Heating Ventilation Air Conditioning)								

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS	New Focus 1.6L	IPM-A(Image Processing Module A)								
FOCUS	New Focus 1.6L	IPM-B(Image Processing Module B)								
FOCUS	New Focus 1.6L	IPC(Instrument Panel Control Module)								
FOCUS	New Focus 1.6L	PAM(Park Aid Module)								
FOCUS	New Focus 1.6L	PDM(Passenger Door Module)								
FOCUS	New Focus 1.6L	PSCM(Power Steering Control Module)								
FOCUS	New Focus 1.6L	RCM(Restraint Control Module)								
FOCUS	New Focus 1.6L	RFA(Remote FunctionActuator)								
FOCUS	New Focus 1.6L	SASM(Steering Angle Sensor Module)								
FOCUS	New Focus 1.6L	SRM(Speech Recognition Module)								
FOCUS	New Focus 1.6L	SOD-L(Side Obstacle Detection Control Module Left)								
FOCUS	New Focus 1.6L	SOD-R(Side Obstacle Detection Control Module Right)								
FOCUS	New Focus 1.6L	TRM(Trailer Module)								
FOCUS	1.6L	PCM(PowerTrain Control Module)								
FOCUS	1.6L	PATS(Passive anti theft system)								
FOCUS	1.6L	ABS(Anti-Lock Brake System)								
FOCUS	1.6L	RCM(Restraint Control Module)								
FOCUS	1.6L	CSM(Central Security Module)								
FOCUS	1.6L	GEM(Generic Electronic Module)								
FOCUS	1.6L	HEC(Hybrid Electrical Cluster)								
FOCUS	1.6L	MC(Message Center)								
FOCUS	1.8L	PCM(PowerTrain Control Module)								
FOCUS	1.8L	PATS(Passive anti theft system)								
FOCUS	1.8L	ABS(Anti-Lock Brake System)								
FOCUS	1.8L	RCM(Restraint Control Module)								
FOCUS	1.8L	CSM(Central Security Module)								
FOCUS	1.8L	GEM(Generic Electronic Module)								
FOCUS	1.8L	HEC(Hybrid Electrical Cluster)								
FOCUS	1.8L	MC(Message Center)								
FOCUS	2.0L	PCM(PowerTrain Control Module)								
FOCUS	2.0L	PATS(Passive anti theft system)								
FOCUS	2.0L	TCM(Transmission control module)								
FOCUS	2.0L	ABS(Anti-Lock Brake System)								
FOCUS	2.0L	EPS(Electronic power steering)								
FOCUS	2.0L	RCM(Restraint Control Module)								
FOCUS	2.0L	CSM(Central Security Module)								
FOCUS	2.0L	GEM(Generic Electronic Module)								
FOCUS	2.0L	IC(Instrument cluster)								
FOCUS	2.0L	DDM(Driver door module)								
FOCUS	2.0L	PDM(Passenger door module)								
FOCUS	2.0L	HEC(Hybrid Electrical Cluster)								
FOCUS	2.0L	MC(Message Center)								
FOCUS	2.0L	ACM(Audio control module)								
FOCUS	2.0L DIESEL	PCM(PowerTrain Control Module)								
FOCUS	2.0L DIESEL	ABS(Anti-Lock Brake System)								
FOCUS	2.0L DIESEL	CDP(Compact Disc Player)								
FOCUS	2.0L DIESEL	CMR(Camera Module Rear)								
FOCUS	2.0L DIESEL	D DCU(Driver Door Control Unit)								
FOCUS	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)								
FOCUS	2.0L DIESEL	EPS(Electronic Power Steering)								
FOCUS	2.0L DIESEL	FACM(Fuel Additive Control Module)								
FOCUS	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)								
FOCUS	2.0L DIESEL	GEM(Generic Electronic Module)								
FOCUS	2.0L DIESEL	HCM(Headlamp Control Module)								
FOCUS	2.0L DIESEL	IC(Instrument Cluster)								
FOCUS	2.0L DIESEL	PDM(Passenger Door Module)								
FOCUS	2.0L DIESEL	PAM(Park Aid Module)								
FOCUS	2.0L DIESEL	RCM(Restraint Control Module)								
FOCUS	2.0L DIESEL	RETM(Rear Entertainment Module)								
FOCUS	2.0L DIESEL	RKE(Remote Keyless Entry)								
FOCUS	2.5L	PCM(PowerTrain Control Module)								
FOCUS	2.5L	PATS(Passive anti theft system)								
FOCUS	2.5L	TCM(Transmission control module)								
FOCUS	2.5L	ABS(Anti-Lock Brake System)								
FOCUS	2.5L	EPS(Electronic power steering)								
FOCUS	2.5L	RCM(Restraint Control Module)								
FOCUS	2.5L	GEM(Generic Electronic Module)								
FOCUS	2.5L	IC(Instrument cluster)								
FOCUS	2.5L	DDM(Driver door module)								

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS	2.5L	PDM(Passenger door module)								
FOCUS	2.5L	MC(Message Center)								
FOCUS	2.5L	ACM(Audio control module)								
ECOSPORT	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)							
ECOSPORT	1.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)							
ECOSPORT	1.0L	ZETEC ROCAM	GEM(Generic Electronic Module)							
ECOSPORT	1.0L	ZETEC ROCAM	IC(Instrument Cluster)							
ECOSPORT	1.0L	ZETEC ROCAM	RCM(Restraint Control Module)							
ECOSPORT	1.4L	DIESEL	PCM(PowerTrain Control Module)							
ECOSPORT	1.4L	DIESEL	ABS(Anti-Lock Brake System)							
ECOSPORT	1.4L	DIESEL	GEM(Generic Electronic Module)							
ECOSPORT	1.4L	DIESEL	IC(Instrument Cluster)							
ECOSPORT	1.4L	DIESEL	RCM(Restraint Control Module)							
ECOSPORT	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)							
ECOSPORT	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)							
ECOSPORT	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)							
ECOSPORT	1.6L	ZETEC ROCAM	IC(Instrument Cluster)							
ECOSPORT	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)							
ECOSPORT	1.6L	FFV	PCM(PowerTrain Control Module)							
ECOSPORT	1.6L	FFV	ABS(Anti-Lock Brake System)							
ECOSPORT	1.6L	FFV	GEM(Generic Electronic Module)							
ECOSPORT	1.6L	FFV	IC(Instrument Cluster)							
ECOSPORT	1.6L	FFV	RCM(Restraint Control Module)							
ECOSPORT	1.6L	FFV	TBM(Tracking And Blocking Module)							
ECOSPORT	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)							
ECOSPORT	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)							
ECOSPORT	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)							
ECOSPORT	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)							
ECOSPORT	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)							
ECOSPORT	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)							
ECOSPORT	2.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)							
ECOSPORT	2.0L	ZETEC ROCAM	IC(Instrument Cluster)							
ECOSPORT	2.0L	ZETEC ROCAM	RCM(Restraint Control Module)							
ECOSPORT	2.0L	FFV	PCM(PowerTrain Control Module)							
ECOSPORT	2.0L	FFV	ABS(Anti-Lock Brake System)							
ECOSPORT	2.0L	FFV	GEM(Generic Electronic Module)							
ECOSPORT	2.0L	FFV	IC(Instrument Cluster)							
ECOSPORT	2.0L	FFV	RCM(Restraint Control Module)							
ECOSPORT	2.0L	FFV	TBM(Tracking And Blocking Module)							
ESCORT-Beta	2.0L	PCM(PowerTrain Control Module)								
ESCORT-Beta	2.0L	ABS(Anti-Lock Brake System)								
ESCORT-Beta	2.0L	ECS(Electronic Crash Sensor)								
ESCORT-Beta	2.0L	PATS(Passive Anti Theft System)								
ESCORT-Beta	2.0L	RAP(Remote Anti-Theft/Personality Module)								
ESCAPE(TRIBUTE)	Up to 2004	PCM(PowerTrain Control Module)								
ESCAPE(TRIBUTE)	Up to 2004	Immobilizer								
ESCAPE(TRIBUTE)	Up to 2004	ABS(Anti-Lock Brake System)								
ESCAPE(TRIBUTE)	Up to 2004	RCM(Restraint Control Module)								
ESCAPE(TRIBUTE)	Up to 2004	GEM(Generic Electronic Module)								
ESCAPE(TRIBUTE)	From 2004	PCM(PowerTrain Control Module)								
ESCAPE(TRIBUTE)	From 2004	PATS(Passive anti theft system)								
ESCAPE(TRIBUTE)	From 2004	ABS(Anti-Lock Brake System)								
ESCAPE(TRIBUTE)	From 2004	RCM(Restraint Control Module)								
ESCAPE(TRIBUTE)	From 2004	IC(Instrument cluster)								
ESCAPE(TRIBUTE)	From 2004	GEM(Generic Electronic Module)								
TERRITORY	SZ-II	PCM(PowerTrain Control Module)								
TERRITORY	SZ-II	TCM(Transmission Control Module)								
TERRITORY	SZ-II	ABS(Anti-Lock Brake System)								
TERRITORY	SZ-II	ACM(Audio Control Module)								
TERRITORY	SZ-II	APIM(Accessory Protocol Interface Module)								
TERRITORY	SZ-II	BEM(Body Electronic Module)								
TERRITORY	SZ-II	FCIM(Front Controls Interface Module)								
TERRITORY	SZ-II	GPSM(Global Positioning System Module)								
TERRITORY	SZ-II	GWM(Gateway Module A)								
TERRITORY	SZ-II	HIM(HVAC Integrated Module)								
TERRITORY	SZ-II	IPC(Instrument Panel Control Module)								
TERRITORY	SZ-II	PAM(Park Aid Module)								
TERRITORY	SZ-II	PSCM(Power Steering Control Module)								
TERRITORY	SZ-II	RCM(Restraint Control Module)								

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
TERRITORY	SZ	PCM(PowerTrain Control Module)								
TERRITORY	SZ	PATS(Passive anti theft system)								
TERRITORY	SZ	TCM(Transmission Control Module)								
TERRITORY	SZ	ABS(Anti-Lock Brake System)								
TERRITORY	SZ	PSCM(Power Steering Control Module)								
TERRITORY	SZ	AWD(All Wheel Drive)								
TERRITORY	SZ	RCM(Restraint Control Module)								
TERRITORY	SZ	IPC(Instrument Cluster)								
TERRITORY	SZ	BEM(Body Electronic Module)								
TERRITORY	SZ	HIM(HVAC Integrated Module)								
TERRITORY	SZ	FDIM(Front Display Interface Moudle)								
TERRITORY	SZ	ACM(Audio Control Module)								
TERRITORY	SY-II	PCM(PowerTrain Control Module)								
TERRITORY	SY-II	TCM(Transmission Control Module)								
TERRITORY	SY-II	ABS(Anti-Lock Brake System)								
TERRITORY	SY-II	RCM(Restraint Control Module)								
TERRITORY	SY-II	BEM(Body Electronic Module)								
TERRITORY	SY-II	IC(Instrument Cluster)								
TERRITORY	SY-II	HIM(HVAC Integrated Module)								
TERRITORY	SY-II	ACM(Audio Control Module)								
TERRITORY	SY	PCM(PowerTrain Control Module)								
TERRITORY	SY	TCM(Transmission Control Module)								
TERRITORY	SY	ABS(Anti-Lock Brake System)								
TERRITORY	SY	RCM(Restraint Control Module)								
TERRITORY	SY	BEM(Body Electronic Module)								
TERRITORY	SY	IC(Instrument Cluster)								
TERRITORY	SY	HIM(HVAC Integrated Module)								
TERRITORY	SY	ACM(Audio Control Module)								
TERRITORY	SX	PCM(PowerTrain Control Module)								
TERRITORY	SX	ABS(Anti-Lock Brake System)								
TERRITORY	SX	RCM(Restraint Control Module)								
TERRITORY	SX	BEM(Body Electronic Module)								
TERRITORY	SX	IC(Instrument Cluster)								
TERRITORY	SX	HIM(HVAC Integrated Module)								
TERRITORY	SX	ACM(Audio Control Module)								
TERRITORY	SX	PAM(Park Aid Module)								
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)							
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)							

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)							
KUGA	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)							
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)								
KUGA	2.0L DIESEL	TCM(Transmission Control Module)								
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)								
KUGA	2.0L DIESEL	ACM(Audio Control Module)								
KUGA	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)								
KUGA	2.0L DIESEL	APIM(Accessory Protocol Interface Module)								
KUGA	2.0L DIESEL	AWD(All Wheel Drive Module)								
KUGA	2.0L DIESEL	BCMii(Body Control Module)								
KUGA	2.0L DIESEL	CCMii(Cruise Control Module)								
KUGA	2.0L DIESEL	CMR(Camera Module Rear)								
KUGA	2.0L DIESEL	D DCU(Driver Door Control Unit)								
KUGA	2.0L DIESEL	DDM(Driver's Door Module)								
KUGA	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)								
KUGA	2.0L DIESEL	EPS(Electronic Power Steering)								
KUGA	2.0L DIESEL	FDSM(Front Distance Sensing Module)								
KUGA	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)								
KUGA	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)								
KUGA	2.0L DIESEL	GEM(Generic Electronic Module)								
KUGA	2.0L DIESEL	GPSM(Global Positioning System Module)								
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)								
KUGA	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)								
KUGA	2.0L DIESEL	IPM-A(Image Processing Module A)								
KUGA	2.0L DIESEL	IPM-B(Image Processing Module B)								
KUGA	2.0L DIESEL	IPC(Instrument Panel Control Module)								
KUGA	2.0L DIESEL	IC(Instrument Cluster)								
KUGA	2.0L DIESEL	PAM(Parking Aid Module)								
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)								
KUGA	2.0L DIESEL	PSCM(Power Steering Control Module)								
KUGA	2.0L DIESEL	RCM(Restraint Control Module)								
KUGA	2.0L DIESEL	RFA(Remote Function Actuator)								
KUGA	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)								
KUGA	2.0L DIESEL	RETM(Rear Entertainment Module)								
KUGA	2.0L DIESEL	SASM(Steering Angle Sensor Module)								
KUGA	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)								
KUGA	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)								
KUGA	2.0L DIESEL	SRM(Speech Recognition Module)								
KUGA	2.0L DIESEL	TRM(Trailer Module)								
KUGA	2.5L	I5	PCM(PowerTrain Control Module)							
KUGA	2.5L	I5	ABS(Anti-Lock Brake System)							
KUGA	2.5L	I5	ACM(Audio Control Module)							
KUGA	2.5L	I5	AWD(All Wheel Drive Module)							
KUGA	2.5L	I5	CMR(Camera Module Rear)							
KUGA	2.5L	I5	D DCU(Driver Door Control Unit)							
KUGA	2.5L	I5	EATC(Electronic Automatic Temperature Control)							
KUGA	2.5L	I5	EPS(Electronic Power Steering)							
KUGA	2.5L	I5	FFH(Fuel Fired Coolant Heating Module)							
KUGA	2.5L	I5	GEM(Generic Electronic Module)							
KUGA	2.5L	I5	HCM(Headlamp Control Module)							
KUGA	2.5L	I5	IC(Instrument Cluster)							
KUGA	2.5L	I5	PAM(Parking Aid Module)							
KUGA	2.5L	I5	PDM(Passenger's Door Module)							
KUGA	2.5L	I5	RCM(Restraint Control Module)							
KUGA	2.5L	I5	RETM(Rear Entertainment Module)							
KUGA	2.5L	I5	RKE(Remote Keyless Entry)							
KUGA	2.5L	I5	SRM(Speech Recognition Module)							
KUGA	2.5L	I5	TCM(Transmission Control Module)							
TRANSIT	1.6L DIESEL	PCM(PowerTrain Control Module)								
TRANSIT	1.6L DIESEL	ABS(Anti-Lock Brake System)								
TRANSIT	1.6L DIESEL	ACM(Audio Control Module)								
TRANSIT	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)								
TRANSIT	1.6L DIESEL	APIM(Accessory Protocol Control Module)								
TRANSIT	1.6L DIESEL	BCMii(Body Control Module)								
TRANSIT	1.6L DIESEL	DDM(Drivers Door Module)								

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
TRANSIT	1.6L DIESEL	FCIM(Front Controls Interface Module)								
TRANSIT	1.6L DIESEL	FDSM(Front Distance Sensing Module)								
TRANSIT	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)								
TRANSIT	1.6L DIESEL	GPSM(Global Positioning System Module)								
TRANSIT	1.6L DIESEL	HCM(Headlamp Control Module)								
TRANSIT	1.6L DIESEL	HVAC(Heating Ventilation Air Conditioning)								
TRANSIT	1.6L DIESEL	IPM-B(Image Processing Module B)								
TRANSIT	1.6L DIESEL	IPC(Instrument Panel Control)								
TRANSIT	1.6L DIESEL	PAM(Park Aid Module)								
TRANSIT	1.6L DIESEL	PDM(Passenger Door Module)								
TRANSIT	1.6L DIESEL	PSCM(Power Steering Control Module)								
TRANSIT	1.6L DIESEL	RCM(Restraint Control Module)								
TRANSIT	1.6L DIESEL	SASM(Steering Angle Sensor Module)								
TRANSIT	1.6L DIESEL	TRM(Trailer Module)								
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Park Aid Module)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Park Aid Module)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)						
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)						
TRANSIT	2.0L	PCM(PowerTrain Control Module)								
TRANSIT	2.0L	PATS(Passive anti theft system)								
TRANSIT	2.0L	ASM(Auto shift manual)								
TRANSIT	2.0L	ABS(Anti-Lock Brake System)								
TRANSIT	2.0L	HEC(Hybrid electrical cluster)								
TRANSIT	2.0L	Passive Antitheft								
TRANSIT	2.2L(Beta)	PCM(PowerTrain Control Module)								
TRANSIT	2.2L(Beta)	ABS(Anti-Lock Brake System)								
TRANSIT	2.2L(Beta)	ACM(Audio Control Module)								
TRANSIT	2.2L(Beta)	BCMii(Body Control Module)								
TRANSIT	2.2L(Beta)	FFH(Fuel Fired Coolant Heating Module)								
TRANSIT	2.2L(Beta)	IPC(Instrument Panel Control)								
TRANSIT	2.2L(Beta)	PAM(Park Aid Module)								
TRANSIT	2.2L(Beta)	RCM(Restraint Control Module)								
TRANSIT	2.2L(Beta)	SRM(Speech Recognition Module)								
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)								
TRANSIT	2.3L DIESEL	PATS(Passive anti theft system)								
TRANSIT	2.3L DIESEL	ASM(Auto shift manual)								
TRANSIT	2.3L DIESEL	ABS(Anti-Lock Brake System)								
TRANSIT	2.3L DIESEL	RCM(Restraint Control Module)								
TRANSIT	2.3L DIESEL	HEC(Hybrid electrical cluster)								
TRANSIT	2.3L DIESEL	IPC(Instrument panel control)								
TRANSIT	2.3L DIESEL	BCMii(Body control module)								
TRANSIT	2.3L DIESEL	ACM(Audio control module)								
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)								
TRANSIT	2.4L DIESEL	PATS(Passive anti theft system)								
TRANSIT	2.4L DIESEL	ASM(Auto shift manual)								
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)								
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)								
TRANSIT	2.4L DIESEL	HEC(Hybrid electrical cluster)								
TRANSIT	2.4L DIESEL	IPC(Instrument panel control)								
TRANSIT	2.4L DIESEL	BCMii(Body control module)								
TRANSIT	2.4L DIESEL	CSM(Central Security Module)								
TRANSIT	2.4L DIESEL	ACM(Audio control module)								
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)	PCM(-2000MY)							
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)	PCM(2000MY-)							
TRANSIT	2.5L DIESEL	PATS(Passive anti theft system)								

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
TRANSIT	2.5L DIESEL	ASM(Auto shift manual)								
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)							
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)							
TRANSIT	2.5L DIESEL	RCM(Restraint Control Module)								
TRANSIT	2.5L DIESEL	HEC(Hybrid electrical cluster)								
TRANSIT	2.5L DIESEL	CSM(Central Security Module)								
TRANSIT	2.5L DIESEL	Passive Antitheft								
TRANSIT	2.5L DIESEL	RIM(Remote Immobilizer Module)								
TRANSIT	2.5L DIESEL	ACM(Audio control module)								
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)								
TRANSIT	3.2L DIESEL	ABS(Anti-Lock Brake System)								
TRANSIT	3.2L DIESEL	ACM(Audio Control Module)								
TRANSIT	3.2L DIESEL	BCMii(Body Control Module)								
TRANSIT	3.2L DIESEL	FFH(Fuel Fired Coolant Heating Module)								
TRANSIT	3.2L DIESEL	IPC(Instrument Panel Control)								
TRANSIT	3.2L DIESEL	PAM(Park Aid Module)								
TRANSIT	3.2L DIESEL	RCM(Restraint Control Module)								
TRANSIT	3.2L DIESEL	SRM(Speech Recognition Module)								
FAIRLANE	AU II	PCM(PowerTrain Control Module)								
FAIRLANE	AU II	ABS(Anti-Lock Brake System)	ABS(With Traction)							
FAIRLANE	AU II	ABS(Anti-Lock Brake System)	ABS(Without Traction)							
FAIRLANE	AU II	RCM(Restraint Control Module)								
FAIRLANE	AU II	BEM(Body Electronic Module)								
FAIRLANE	AU II	IC(Instrument Cluster)								
FAIRLANE	AU II	ACM(Audio Control Module)								
FAIRLANE	AU	PCM(PowerTrain Control Module)								
FAIRLANE	AU	ABS(Anti-Lock Brake System)	ABS(With Traction)							
FAIRLANE	AU	ABS(Anti-Lock Brake System)	ABS(Without Traction)							
FAIRLANE	AU	RCM(Restraint Control Module)								
FAIRLANE	AU	BEM(Body Electronic Module)	BEM(With Smartshield)							
FAIRLANE	AU	BEM(Body Electronic Module)	BEM(Without Smartshield)							
FAIRLANE	AU	IC(Instrument Cluster)								
FAIRMONT	BA	PCM(PowerTrain Control Module)								
FAIRMONT	BA	ABS(Anti-Lock Brake System)								
FAIRMONT	BA	RCM(Restraint Control Module)								
FAIRMONT	BA	BEM(Body Electronic Module)								
FAIRMONT	BA	IC(Instrument Cluster)								
FAIRMONT	BA	HIM(HVAC Integrated Module)								
FAIRMONT	BA	ACM(Audio Control Module)								
FAIRMONT	BA	PAM(Park Aid Module)								
FAIRMONT	AU II	PCM(PowerTrain Control Module)								
FAIRMONT	AU II	ABS(Anti-Lock Brake System)	ABS(With Traction)							
FAIRMONT	AU II	ABS(Anti-Lock Brake System)	ABS(Without Traction)							
FAIRMONT	AU II	RCM(Restraint Control Module)								
FAIRMONT	AU II	BEM(Body Electronic Module)								
FAIRMONT	AU II	IC(Instrument Cluster)								
FAIRMONT	AU II	ACM(Audio Control Module)								
FAIRMONT	AU	PCM(PowerTrain Control Module)								
FAIRMONT	AU	ABS(Anti-Lock Brake System)	ABS(With Traction)							
FAIRMONT	AU	ABS(Anti-Lock Brake System)	ABS(Without Traction)							
FAIRMONT	AU	RCM(Restraint Control Module)								
FAIRMONT	AU	BEM(Body Electronic Module)	BEM(With Smartshield)							
FAIRMONT	AU	BEM(Body Electronic Module)	BEM(Without Smartshield)							
FAIRMONT	AU	IC(Instrument Cluster)								
LTD	AU II	PCM(PowerTrain Control Module)								
LTD	AU II	ABS(Anti-Lock Brake System)	ABS(With Traction)							
LTD	AU II	ABS(Anti-Lock Brake System)	ABS(Without Traction)							
LTD	AU II	RCM(Restraint Control Module)								
LTD	AU II	BEM(Body Electronic Module)								
LTD	AU II	IC(Instrument Cluster)								
LTD	AU II	ACM(Audio Control Module)								
LTD	AU	PCM(PowerTrain Control Module)								
LTD	AU	ABS(Anti-Lock Brake System)	ABS(With Traction)							
LTD	AU	ABS(Anti-Lock Brake System)	ABS(Without Traction)							
LTD	AU	RCM(Restraint Control Module)								
LTD	AU	BEM(Body Electronic Module)	BEM(With Smartshield)							
LTD	AU	BEM(Body Electronic Module)	BEM(Without Smartshield)							
LTD	AU	IC(Instrument Cluster)								
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)						

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger Door Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)						
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger Door Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)						
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Park Aid Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)						

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger Door Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)						
MONDEO	2012 MY	2.0L DIESEL	PCM(PowerTrain Control Module)							
MONDEO	2012 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)							
MONDEO	2012 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)							
MONDEO	2012 MY	2.0L DIESEL	BCMii(Body Control Module)							
MONDEO	2012 MY	2.0L DIESEL	CCMii(Cruise Control Module)							
MONDEO	2012 MY	2.0L DIESEL	CMR(Camera Module Rear)							
MONDEO	2012 MY	2.0L DIESEL	DDM(Driver's Door Module)							
MONDEO	2012 MY	2.0L DIESEL	DSM(Driver's Seat Module)							
MONDEO	2012 MY	2.0L DIESEL	HCM(Headlamp Control Module)							
MONDEO	2012 MY	2.0L DIESEL	HVAC(Heating Ventlation Air Conditioning)							
MONDEO	2012 MY	2.0L DIESEL	IPM-A(Image Processing Module A)							
MONDEO	2012 MY	2.0L DIESEL	IPC(Instrument Panel Control)							
MONDEO	2012 MY	2.0L DIESEL	PAM(Park Aid Module)							
MONDEO	2012 MY	2.0L DIESEL	PBM(Parking Brake Control Module)							
MONDEO	2012 MY	2.0L DIESEL	PDM(Passenger Door Module)							
MONDEO	2012 MY	2.0L DIESEL	PSCM(Power Steering Control Module)							
MONDEO	2012 MY	2.0L DIESEL	RCM(Restraint Control Module)							
MONDEO	2012 MY	2.0L DIESEL	RFA(Remote FunctionActuator)							
MONDEO	2012 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)							
MONDEO	2012 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)							
MONDEO	2012 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)							
MONDEO	2012 MY	2.0L DIESEL	SRM(Speech Recognition Module)							
MONDEO	2012 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)							
MONDEO	2012 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)							
MONDEO	2012 MY	2.0L DIESEL	TCM(Transmission Control Module)							
MONDEO	2012 MY	2.0L DIESEL	TRM(Trailer Module)							
MONDEO	2012 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)							
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger Door Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)						
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)						

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Park Aid Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger Door Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)						
MONDEO	2011 MY	2.0L DIESEL	PCM(PowerTrain Control Module)							
MONDEO	2011 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)							
MONDEO	2011 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)							
MONDEO	2011 MY	2.0L DIESEL	BCMii(Body Control Module)							
MONDEO	2011 MY	2.0L DIESEL	CCMii(Cruise Control Module)							
MONDEO	2011 MY	2.0L DIESEL	CMR(Camera Module Rear)							
MONDEO	2011 MY	2.0L DIESEL	DDM(Driver's Door Module)							
MONDEO	2011 MY	2.0L DIESEL	DSM(Driver's Seat Module)							
MONDEO	2011 MY	2.0L DIESEL	HCM(Headlamp Control Module)							
MONDEO	2011 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)							
MONDEO	2011 MY	2.0L DIESEL	IPM-A(Image Processing Module A)							
MONDEO	2011 MY	2.0L DIESEL	IPC(Instrument Panel Control)							
MONDEO	2011 MY	2.0L DIESEL	PAM(Park Aid Module)							
MONDEO	2011 MY	2.0L DIESEL	PBM(Parking Brake Control Module)							
MONDEO	2011 MY	2.0L DIESEL	PDM(Passenger Door Module)							
MONDEO	2011 MY	2.0L DIESEL	PSCM(Power Steering Control Module)							
MONDEO	2011 MY	2.0L DIESEL	RCM(Restraint Control Module)							
MONDEO	2011 MY	2.0L DIESEL	RFA(Remote FunctionActuator)							
MONDEO	2011 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)							
MONDEO	2011 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)							
MONDEO	2011 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)							
MONDEO	2011 MY	2.0L DIESEL	SRM(Speech Recognition Module)							
MONDEO	2011 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)							
MONDEO	2011 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)							
MONDEO	2011 MY	2.0L DIESEL	TCM(Transmission Control Module)							
MONDEO	2011 MY	2.0L DIESEL	TRM(Trailer Module)							
MONDEO	2011 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)							
MONDEO	2011 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)							
MONDEO	2011 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)							
MONDEO	2011 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)							
MONDEO	2011 MY	2.3L GASOLINE	BCMii(Body Control Module)							
MONDEO	2011 MY	2.3L GASOLINE	CCMii(Cruise Control Module)							
MONDEO	2011 MY	2.3L GASOLINE	CMR(Camera Module Rear)							
MONDEO	2011 MY	2.3L GASOLINE	DDM(Driver Door Module)							
MONDEO	2011 MY	2.3L GASOLINE	DSM(Driver Seat Module)							
MONDEO	2011 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)							
MONDEO	2011 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)							
MONDEO	2011 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)							
MONDEO	2011 MY	2.3L GASOLINE	PAM(Park Aid Module)							
MONDEO	2011 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)							
MONDEO	2011 MY	2.3L GASOLINE	PDM(Passenger Door Module)							
MONDEO	2011 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)							
MONDEO	2011 MY	2.3L GASOLINE	RCM(Restraint Control Module)							
MONDEO	2011 MY	2.3L GASOLINE	RFA(Remote Function Actuator)							
MONDEO	2011 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)							
MONDEO	2011 MY	2.3L GASOLINE	SRM(Speech Recognition Module)							

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2011 MY	2.3L GASOLINE	TCM(Transmission Control Module)							
MONDEO	2011 MY	2.3L GASOLINE	TRM(Trailer Module)							
MONDEO	2011 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)							
MONDEO	2011 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA							
MONDEO	2011 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)							
MONDEO	2011 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)							
MONDEO	2011 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)							
MONDEO	2011 MY	2.5L GASOLINE	BCMii(Body Control Module)							
MONDEO	2011 MY	2.5L GASOLINE	CCMii(Cruise Control Module)							
MONDEO	2011 MY	2.5L GASOLINE	CMR(Camera Module Rear)							
MONDEO	2011 MY	2.5L GASOLINE	DDM(Driver's Door Module)							
MONDEO	2011 MY	2.5L GASOLINE	DSM(Driver's Seat Module)							
MONDEO	2011 MY	2.5L GASOLINE	HCM(Headlamp Control Module)							
MONDEO	2011 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)							
MONDEO	2011 MY	2.5L GASOLINE	IPC(Instrument Panel Control)							
MONDEO	2011 MY	2.5L GASOLINE	PAM(Park Aid Module)							
MONDEO	2011 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)							
MONDEO	2011 MY	2.5L GASOLINE	PDM(Passenger Door Module)							
MONDEO	2011 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)							
MONDEO	2011 MY	2.5L GASOLINE	RCM(Restraint Control Module)							
MONDEO	2011 MY	2.5L GASOLINE	RFA(Remote FunctionActuator)							
MONDEO	2011 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)							
MONDEO	2011 MY	2.5L GASOLINE	SRM(Speech Recognition Module)							
MONDEO	2011 MY	2.5L GASOLINE	TCM(Transmission Control Module)							
MONDEO	2011 MY	2.5L GASOLINE	TRM(Trailer Module)							
MONDEO	2011 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)							
MONDEO	2011 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA							
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger Door Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)						
MONDEO	2010 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Park Aid Module)						

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger Door Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)						
MONDEO	2010 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)						
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)							
MONDEO	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)							
MONDEO	2010 MY	2.5L I5	PCM(PowerTrain Control Module)							
MONDEO	2010 MY	2.5L I5	ABS(Anti-Lock Brake System)							
MONDEO	2010 MY	2.5L I5	AHCM(Auxiliary Heater Control Module)							
MONDEO	2010 MY	2.5L I5	BCMii(Body Control Module)							
MONDEO	2010 MY	2.5L I5	CCMii(Cruise Control Module)							
MONDEO	2010 MY	2.5L I5	CMR(Camera Module Rear)							
MONDEO	2010 MY	2.5L I5	DDM(Driver's Door Module)							
MONDEO	2010 MY	2.5L I5	DSM(Driver's Seat Module)							
MONDEO	2010 MY	2.5L I5	HCM(Headlamp Control Module)							
MONDEO	2010 MY	2.5L I5	HVAC(Heating Ventilation Air Conditioning)							
MONDEO	2010 MY	2.5L I5	IPC(Instrument Panel Control Module)							
MONDEO	2010 MY	2.5L I5	PAM(Parking Aid Module)							
MONDEO	2010 MY	2.5L I5	PBM(Parking Brake Control Module)							
MONDEO	2010 MY	2.5L I5	PDM(Passenger's Door Module)							
MONDEO	2010 MY	2.5L I5	PSCM(Power Steering Control Module)							
MONDEO	2010 MY	2.5L I5	RCM(Restraint Control Module)							
MONDEO	2010 MY	2.5L I5	RFA(Remote Function Actuator)							
MONDEO	2010 MY	2.5L I5	SASM(Steering Angle Sensor Module)							
MONDEO	2010 MY	2.5L I5	SRM(Speech Recognition Module)							
MONDEO	2010 MY	2.5L I5	TCM(Transmission Control Module)							
MONDEO	2010 MY	2.5L I5	TRM(Trailer Module)							
MONDEO	2010 MY	2.5L I5	VDM(Vehicle Dynamic Module)							
MONDEO	2010 MY	DIESEL(Beta)	PCM(PowerTrain Control Module)							
MONDEO	2010 MY	DIESEL(Beta)	PATS(Passive anti theft system)							
MONDEO	2010 MY	DIESEL(Beta)	ABS(Anti-Lock Brake System)							
MONDEO	2010 MY	DIESEL(Beta)	AHCM(Auxiliary Heater Control Module)							
MONDEO	2010 MY	DIESEL(Beta)	BCMii(Body Control Module)							
MONDEO	2010 MY	DIESEL(Beta)	CCMii(Cruise Control Module)							
MONDEO	2010 MY	DIESEL(Beta)	CMR(Camera Module Rear)							
MONDEO	2010 MY	DIESEL(Beta)	DDM(Driver Door Module)							
MONDEO	2010 MY	DIESEL(Beta)	DSM(Driver Seat Module)							
MONDEO	2010 MY	DIESEL(Beta)	HCM(HeadLamp Control Module)							
MONDEO	2010 MY	DIESEL(Beta)	HVAC(Heating Ventilation Air Conditioning)							
MONDEO	2010 MY	DIESEL(Beta)	IPC(Instrument Panel Control Module)							
MONDEO	2010 MY	DIESEL(Beta)	PAM(Parking Aid Module)							

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2010 MY	DIESEL(Beta)	PBM(Parking Brake Control Module)							
MONDEO	2010 MY	DIESEL(Beta)	PDM(Passenger Door Module)							
MONDEO	2010 MY	DIESEL(Beta)	PSCM(Power Steering Control Module)							
MONDEO	2010 MY	DIESEL(Beta)	RCM(Rastraint Control Module)							
MONDEO	2010 MY	DIESEL(Beta)	RFA(Remote Function Actuator)							
MONDEO	2010 MY	DIESEL(Beta)	SASM(Steering Angle Sensor Module)							
MONDEO	2010 MY	DIESEL(Beta)	SRM(Speech Recognition Module)							
MONDEO	2010 MY	DIESEL(Beta)	TCM(Transmission Control Module)							
MONDEO	2010 MY	DIESEL(Beta)	TRM(Trailer Module)							
MONDEO	2010 MY	DIESEL(Beta)	VDM(Vehicle Dynamics Module)							
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)							
MONDEO	2009 MY	2.0L DIESEL	PATS(Passive anti theft system)							
MONDEO	2009 MY	2.0L DIESEL	TCM(Transmission control module)							
MONDEO	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)							
MONDEO	2009 MY	2.0L DIESEL	SASM(Steering angle sensor module)							
MONDEO	2009 MY	2.0L DIESEL	RCM(Restraint control module)							
MONDEO	2009 MY	2.0L DIESEL	IPC(Instrument panel control)							
MONDEO	2009 MY	2.0L DIESEL	BCMii(Body control module)							
MONDEO	2009 MY	2.0L DIESEL	DDM(Driver door module)							
MONDEO	2009 MY	2.0L DIESEL	PDM(Passener door module)							
MONDEO	2009 MY	2.0L DIESEL	SRM(Speech recognition module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	PCM(PowerTrain Control Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	PATS(Passive anti theft system)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	ABS(Anti-Lock Brake System)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	AHCM(Auxiliary Heater Control Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	BCMii(Body Control Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	CCMii(Cruise Control Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	CMR(Camera Module Rear)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	DDM(Driver Door Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	DSM(Driver Seat Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	HCM(HeadLamp Control Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	HVAC(Heating Ventilation Air Conditioning)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	IPC(Instrument Panel Control Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	PAM(Parking Aid Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	PBM(Parking Brake Control Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	PDM(Passenger Door Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	PSCM(Power Steering Control Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	RCM(Rastraint Control Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	RFA(Remote Function Actuator)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	SASM(Steering Angle Sensor Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	SRM(Speech Recognition Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	TCM(Transmission Control Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	TRM(Trailer Module)							
MONDEO	2007 MY	2.3L DURATEC-HE/I4(Beta)	VDM(Vehicle Dynamics Module)							
MONDEO	2003 MY	2.0L Duratorq-Common Diesel	PCM(PowerTrain Control Module)							
MONDEO	2003 MY	2.0L Duratorq-Common Diesel	ABS(Anti-Lock Brake System)							
MONDEO	2003 MY	2.0L Duratorq-Common Diesel	RCM(Restraint Control Module)							
MONDEO	2003 MY	2.0L Duratorq-Common Diesel	GEM(Generic Electronic Module)							
MONDEO	2003 MY	2.0L Duratorq-Common Diesel	HEC(Hybrid Electrical Cluster)							
MONDEO	2003 MY	3.0L Duratec-ST	PCM(PowerTrain Control Module)							
MONDEO	2003 MY	3.0L Duratec-ST	ABS(Anti-Lock Brake System)							
MONDEO	2003 MY	3.0L Duratec-ST	ACM(Audio Control Module)							
MONDEO	2003 MY	3.0L Duratec-ST	CDP(Compact Disc Player)							
MONDEO	2003 MY	3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)							
MONDEO	2003 MY	3.0L Duratec-ST	GDM(Generic Display Module)							
MONDEO	2003 MY	3.0L Duratec-ST	GEM(Generic Electronic Module)							
MONDEO	2003 MY	3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)							
MONDEO	2003 MY	3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)							
MONDEO	2003 MY	3.0L Duratec-ST	NAV(Navigation System)							
MONDEO	2003 MY	3.0L Duratec-ST	RCM(Restraint Control Module)							
MONDEO	2003 MY	3.0L Duratec-ST	RETM(Rear Entertainment Module)							
MONDEO	2003 MY	3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)							
MONDEO	2003 MY	3.0L Duratec-ST	SRM(Speech Recognition Module)							
MONDEO	2002 MY	2.0L DURATEC HE-I4	PCM(PowerTrain Control Module)							
MONDEO	2002 MY	2.0L DURATEC HE-I4	ABS(Anti-Lock Brake System)							
MONDEO	2002 MY	2.0L DURATEC HE-I4	EATC(Electronic Automatic Temperature Control)							
MONDEO	2002 MY	2.0L DURATEC HE-I4	GEM(Generic Electronic Module)							
MONDEO	2002 MY	2.0L DURATEC HE-I4	HCM(Headlamp Control Module)							
MONDEO	2002 MY	2.0L DURATEC HE-I4	RCM(Restraint Control Module)							

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2000 MY	1.8L	PCM(PowerTrain Control Module)							
MONDEO	2000 MY	1.8L	ABS(Anti-Lock Brake System)							
MONDEO	2000 MY	1.8L	CSM(Central Security Module)							
MONDEO	2000 MY	1.8L DIESEL	PCM(PowerTrain Control Module)							
MONDEO	2000 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)							
MONDEO	2000 MY	1.8L DIESEL	CSM(Central Security Module)							
MONDEO	2000 MY	1.8L DIESEL	Passive Antitheft							
MONDEO	2000 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)							
MONDEO	2000 MY	2.0L	PCM(PowerTrain Control Module)							
MONDEO	2000 MY	2.0L	ABS(Anti-Lock Brake System)							
MONDEO	2000 MY	2.0L	CSM(Central Security Module)							
MONDEO	2000 MY	2.5L	PCM(PowerTrain Control Module)							
MONDEO	2000 MY	2.5L	ABS(Anti-Lock Brake System)							
MONDEO	2000 MY	2.5L	CSM(Central Security Module)							
MONDEO	1999 MY	1.8L	PCM(PowerTrain Control Module)							
MONDEO	1999 MY	1.8L	ABS(Anti-Lock Brake System)							
MONDEO	1999 MY	1.8L	CSM(Central Security Module)							
MONDEO	1999 MY	1.8L DIESEL	PCM(PowerTrain Control Module)							
MONDEO	1999 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)							
MONDEO	1999 MY	1.8L DIESEL	CSM(Central Security Module)							
MONDEO	1999 MY	1.8L DIESEL	Passive Antitheft							
MONDEO	1999 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)							
MONDEO	1999 MY	2.0L	PCM(PowerTrain Control Module)							
MONDEO	1999 MY	2.0L	ABS(Anti-Lock Brake System)							
MONDEO	1999 MY	2.0L	CSM(Central Security Module)							
MONDEO	1999 MY	2.5L	PCM(PowerTrain Control Module)							
MONDEO	1999 MY	2.5L	ABS(Anti-Lock Brake System)							
MONDEO	1999 MY	2.5L	CSM(Central Security Module)							
MONDEO	1998 MY	1.8L	PCM(PowerTrain Control Module)							
MONDEO	1998 MY	1.8L	ABS(Anti-Lock Brake System)							
MONDEO	1998 MY	1.8L	CSM(Central Security Module)							
MONDEO	1998 MY	1.8L DIESEL	PCM(PowerTrain Control Module)							
MONDEO	1998 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)							
MONDEO	1998 MY	1.8L DIESEL	CSM(Central Security Module)							
MONDEO	1998 MY	1.8L DIESEL	Passive Antitheft							
MONDEO	1998 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)							
MONDEO	1998 MY	2.0L	PCM(PowerTrain Control Module)							
MONDEO	1998 MY	2.0L	ABS(Anti-Lock Brake System)							
MONDEO	1998 MY	2.0L	CSM(Central Security Module)							
MONDEO	1998 MY	2.5L	PCM(PowerTrain Control Module)							
MONDEO	1998 MY	2.5L	ABS(Anti-Lock Brake System)							
MONDEO	1998 MY	2.5L	CSM(Central Security Module)							
MONDEO	1997 MY	1.8L	PCM(PowerTrain Control Module)							
MONDEO	1997 MY	1.8L	ABS(Anti-Lock Brake System)							
MONDEO	1997 MY	1.8L DIESEL	PCM(PowerTrain Control Module)							
MONDEO	1997 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)							
MONDEO	1997 MY	1.8L DIESEL	Passive Antitheft							
MONDEO	1997 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)							
MONDEO	1997 MY	2.0L	PCM(PowerTrain Control Module)							
MONDEO	1997 MY	2.0L	ABS(Anti-Lock Brake System)							
MONDEO	1997 MY	2.5L	PCM(PowerTrain Control Module)							
MONDEO	1997 MY	2.5L	ABS(Anti-Lock Brake System)							
EXPLORER	2000 MY	PCM(PowerTrain Control Module)								
EXPLORER	2000 MY	ABS(Anti-Lock Brake System)								
EXPLORER	2000 MY	RCM(Restraint Control Module)								
EXPLORER	2000 MY	RIM(Remote Immobilizer Module)								
EXPLORER	2000 MY	GEM(Generic Electronic Module)								
EXPLORER	2000 MY	PAM(Park Aid Module)								
EXPLORER	2000 MY	Passive Antitheft								
EXPLORER	1999 MY	PCM(PowerTrain Control Module)								
EXPLORER	1999 MY	ABS(Anti-Lock Brake System)								
EXPLORER	1999 MY	RCM(Restraint Control Module)								
EXPLORER	1999 MY	RIM(Remote Immobilizer Module)								
EXPLORER	1999 MY	PAM(Park Aid Module)								
EXPLORER	1998 MY	PCM(PowerTrain Control Module)								
EXPLORER	1998 MY	ABS(Anti-Lock Brake System)								
EXPLORER	1998 MY	RCM(Restraint Control Module)								
EXPLORER	1998 MY	RIM(Remote Immobilizer Module)								
EXPLORER	1997 MY	PCM(PowerTrain Control Module)								

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
EXPLORER	1997 MY	ABS(Anti-Lock Brake System)								
EXPLORER	1997 MY	RCM(Restraint Control Module)								
EXPLORER	1997 MY	RIM(Remote Immobilizer Module)								
KA	2000 MY	PCM(PowerTrain Control Module)								
KA	2000 MY	ABS(Anti-Lock Brake System)								
KA	2000 MY	RCM(Restraint Control Module)								
KA	1999 MY	PCM(PowerTrain Control Module)								
KA	1999 MY	ABS(Anti-Lock Brake System)								
TAURUS	1998 MY	PCM(PowerTrain Control Module)								
TAURUS	1998 MY	ABS(Anti-Lock Brake System)								
TAURUS	1998 MY	RCM(Restraint Control Module)								
TAURUS	1998 MY	RIM(Remote Immobilizer Module)								
TAURUS	1997 MY	PCM(PowerTrain Control Module)								
TAURUS	1997 MY	ABS(Anti-Lock Brake System)								
TAURUS	1997 MY	RCM(Restraint Control Module)								
TAURUS	1997 MY	RIM(Remote Immobilizer Module)								
TAURUS	1996 MY	PCM(PowerTrain Control Module)								
TAURUS	1996 MY	ABS(Anti-Lock Brake System)								
TAURUS	1996 MY	RCM(Restraint Control Module)								
TAURUS	1996 MY	RIM(Remote Immobilizer Module)								
BETA-TEST	FOCUS-1.6L Zetec Rocam	PCM(PowerTrain Control Module)								
BETA-TEST	FOCUS-1.6L Zetec Rocam	ABS(Anti-Lock Brake System)								
BETA-TEST	FOCUS-1.6L Zetec Rocam	EATC(Electronic Automatic Temperature Control)								
BETA-TEST	FOCUS-1.6L Zetec Rocam	GEM(Generic Electronic Module)								
BETA-TEST	FOCUS-1.6L Zetec Rocam	HCM(Headlamp Control Module)								
BETA-TEST	FOCUS-1.6L Zetec Rocam	MC(Message Center)								
BETA-TEST	FOCUS-1.6L Zetec Rocam	RCM(Restraint Control Module)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ACM(Audio Control Module)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CDP(Compact Disc Player)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CMR(Camera Module Rear)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	D_DCU(Driver Door Control Unit)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EPS(Electronic Power Steering)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	FFH(Fuel Fired Coolant Heating Module)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	HCM(Headlamp Control Module)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	IC(Instrument Cluster)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PAM(Park Aid Module)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PDM(Passenger Door Module)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RCM(Restraint Control Module)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RETM(Rear Entertainment Module)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RKE(Remote Keyless Entry)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GDM(Generic Display Module)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	NAV(Navigation System)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RL_DCU(Rear Left Door Control Unit)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RR_DCU(Rear Right Door Control Unit)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)								
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	TCM(Transmission Control Module)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PCM(PowerTrain Control Module)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ABS(Anti-Lock Brake System)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ACM(Audio Control Module)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CDP(Compact Disc Player)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CMR(Camera Module Rear)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	D_DCU(Driver Door Control Unit)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EATC(Electronic Automatic Temperature Control)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EPS(Electronic Power Steering)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FACM(Fuel Additive Control Module)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	GEM(Generic Electronic Module)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	HCM(Headlamp Control Module)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	IC(Instrument Cluster)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PAM(Park Aid Module)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PDM(Passenger Door Module)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RCM(Restraint Control Module)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RETM(Rear Entertainment Module)								
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RKE(Remote Keyless Entry)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PCM(PowerTrain Control Module)								

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ABS(Anti-Lock Brake System)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ACM(Audio Control Module)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	CDP(Compact Disc Player)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EPS(Electronic Power Steering)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GDM(Generic Display Module)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GEM(Generic Electronic Module)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	IC(Instrument Cluster)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	NAV(Navigation System)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PAM(Park Aid Module)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PDM(Passenger Door Module)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RETM(Rear Entertainment Module)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RKE(Remote Keyless Entry)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SRM(Speech Recognition Module)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	HCM(Headlamp Control Module)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RCM(Restraint Control Module)								
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	TCM(Transmission Control Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PCM(PowerTrain Control Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ABS(Anti-Lock Brake System)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ACM(Audio Control Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	CDP(Compact Disc Player)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EPS(Electronic Power Steering)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GDM(Generic Display Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GEM(Generic Electronic Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	IC(Instrument Cluster)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	NAV(Navigation System)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PAM(Park Aid Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PDM(Passenger Door Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RETM(Rear Entertainment Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RKE(Remote Keyless Entry)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RL_DCU(Rear Left Door Control Unit)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RR_DCU(Rear Right Door Control Unit)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SRM(Speech Recognition Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	HCM(Headlamp Control Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RCM(Restraint Control Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PCM(Powertrain Control Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ABS(Anti-Lock Brake System)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ACM(Audio Control Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	D_DCU(Driver Door Control Unit)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EATC(Electronic Automatic Temperature Control)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EPS(Electronic power steering)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	GEM(Generic Electronic Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	HCM(Headlamp Control Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	IC(Instrument Cluster)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PAM(Park Aid Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PDM(Passenger Door Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RCM(Restraint Control Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RKE(Remote Keyless Entry)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TBM(Tracking and Blocking Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TCM(Transmission Control Module)								
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PATS(Passive Anti Theft System)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PCM(PowerTrain Control Module)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	ABS(Anti-Lock Brake System)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CDP(Compact Disc Player)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CMR(Camera Module Rear)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	D_DCU(Driver Door Control Unit)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EATC(Electronic Automatic Temperature Control)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EPS(Electronic Power Steering)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FACM(Fuel Additive Control Module)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	GEM(Generic Electronic Module)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	HCM(Headlamp Control Module)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	IC(Instrument Cluster)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PDM(Passenger Door Module)								

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PAM(Park Aid Module)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RCM(Restraint Control Module)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RETM(Rear Entertainment Module)								
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RKE(Remote Keyless Entry)								
BETA-TEST	FUSION GASOLINE1.4L	PCM(Powertrain Control Module)								
BETA-TEST	FUSION GASOLINE1.4L	ABS(Anti-Lock Brake System)								
BETA-TEST	FUSION GASOLINE1.4L	ACM(Audio Control Module)								
BETA-TEST	FUSION GASOLINE1.4L	APIM(Accessory Protocol Control Module)								
BETA-TEST	FUSION GASOLINE1.4L	BCMii(Body Control Module)								
BETA-TEST	FUSION GASOLINE1.4L	DDM(Driver's Door Module)								
BETA-TEST	FUSION GASOLINE1.4L	FDSM(Front Distance Sensing Module)								
BETA-TEST	FUSION GASOLINE1.4L	FCDIM(Front Control-Diplay Interface Module)								
BETA-TEST	FUSION GASOLINE1.4L	GPSM(Global Positioning System Module)								
BETA-TEST	FUSION GASOLINE1.4L	GWM(Gateway Module A)								
BETA-TEST	FUSION GASOLINE1.4L	HVAC(Heating Ventilation Air Conditioning)								
BETA-TEST	FUSION GASOLINE1.4L	IPC(Instrument Panel Control Module)								
BETA-TEST	FUSION GASOLINE1.4L	PDM(Passenger Door Module)								
BETA-TEST	FUSION GASOLINE1.4L	PSCM(Power Steering Control Module)								
BETA-TEST	FUSION GASOLINE1.4L	RCM(Restraint Control Module)								
BETA-TEST	FUSION GASOLINE1.4L	RFA(Remote Function Actuator)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	TCM(Transmission Control Module)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IC(Instrument Cluster)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	GEM(Generic Electronic Module)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ACM(Audio Control Module)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	BCMii(Body Control Module)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	FCDIM(Front Control-Diplay Interface Module)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IPC(Instrument Panel Control Module)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PSCM(Power Steering Control Module)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RCM(Retraint Control Module)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RFA(Remote Function Actuator)								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SRM(Speech Recognition Module)								
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)								
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	TCM(Transmission Control Module)								
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)								
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	IC(Instrument Cluster)								
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ACM(Audio Control Module)								
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)								
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)								
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)								
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)								
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)								
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)								
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)								
BETA-TEST	FIESTA 1.6L DURATEC 16V	PCM(PowerTrain Control Module)								
BETA-TEST	FIESTA 1.6L DURATEC 16V	TCM(Transmission Control Module)								
BETA-TEST	FIESTA 1.6L DURATEC 16V	ABS(Anti-Lock Brake System)								
BETA-TEST	FIESTA 1.6L DURATEC 16V	IC(Instrument Cluster)								
BETA-TEST	FIESTA 1.6L DURATEC 16V	ACM(Audio Control Module)								
BETA-TEST	FIESTA 1.6L DURATEC 16V	EATC(Electronic Automatic Temperature Control)								
BETA-TEST	FIESTA 1.6L DURATEC 16V	GEM(Generic Electronic Module)								
BETA-TEST	FIESTA 1.6L DURATEC 16V	SRM(Speech Recognition Module)								
BETA-TEST	FIESTA 1.6L DURATEC 16V	PATS(Passive Anti Theft System)								
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PCM(PowerTrain Control Module)								
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ABS(Anti-Lock Brake System)								
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ACM(Audio Control Module)								
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	EATC(Electronic Automatic Temperature Control)								
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	GEM(Generic Electronic Module)								
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	IC(Instrument Cluster)								
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SRM(Speech Recognition Module)								
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PATS(Passive Anti Theft System)								
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PCM(PowerTrain Control Module)								
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	ABS(Anti-Lock Brake System)								
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	IC(Instrument Cluster)								
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RCM(Restraint Control Module)								
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RKE(Remote Keyless Entry)								
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	TCM(Transmission Control Module)								

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PATS(Passive Anti Theft System)								
BETA-TEST	MONDEO-2.0L DIESEL	PCM(PowerTrain Control Module)								
BETA-TEST	MONDEO-2.0L DIESEL	ABS(Anti-Lock Brake System)								
BETA-TEST	MONDEO-2.0L DIESEL	AHCM(Auxiliary Heater Control Module)								
BETA-TEST	MONDEO-2.0L DIESEL	BCMii(Body Control Module)								
BETA-TEST	MONDEO-2.0L DIESEL	CCMii(Cruise Control Module)								
BETA-TEST	MONDEO-2.0L DIESEL	CMR(Camera Module Rear)								
BETA-TEST	MONDEO-2.0L DIESEL	DDM(Driver's Door Module)								
BETA-TEST	MONDEO-2.0L DIESEL	DSM(Driver's Seat Module)								
BETA-TEST	MONDEO-2.0L DIESEL	HCM(Headlamp Control Module)								
BETA-TEST	MONDEO-2.0L DIESEL	HVAC(Heating Ventlation Air Conditioning)								
BETA-TEST	MONDEO-2.0L DIESEL	IPC(Instrument Panel Control)								
BETA-TEST	MONDEO-2.0L DIESEL	PAM(Park Aid Module)								
BETA-TEST	MONDEO-2.0L DIESEL	PBM(Parking Brake Control Module)								
BETA-TEST	MONDEO-2.0L DIESEL	PDM(Passenger Door Module)								
BETA-TEST	MONDEO-2.0L DIESEL	PSCM(Power Steering Control Module)								
BETA-TEST	MONDEO-2.0L DIESEL	RCM(Restraint Control Module)								
BETA-TEST	MONDEO-2.0L DIESEL	RFA(Remote FunctionActuator)								
BETA-TEST	MONDEO-2.0L DIESEL	SASM(Steering Angle Sensor Module)								
BETA-TEST	MONDEO-2.0L DIESEL	SRM(Speech Recognition Module)								
BETA-TEST	MONDEO-2.0L DIESEL	TCM(Transmission Control Module)								
BETA-TEST	MONDEO-2.0L DIESEL	TRM(Trailer Module)								
BETA-TEST	MONDEO-2.0L DIESEL	VDM(Vehicle Dynamic Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	PCM(PowerTrain Control Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	ABS(Anti-Lock Brake System)								
BETA-TEST	MONDEO-2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	BCMii(Body Control Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	CCMii(Cruise Control Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	CMR(Camera Module Rear)								
BETA-TEST	MONDEO-2.5L GASOLINE	DDM(Driver's Door Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	DSM(Driver's Seat Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	HCM(Headlamp Control Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	HVAC(Heating Ventlation Air Conditioning)								
BETA-TEST	MONDEO-2.5L GASOLINE	IPC(Instrument Panel Control)								
BETA-TEST	MONDEO-2.5L GASOLINE	PAM(Park Aid Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	PBM(Parking Brake Control Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	PDM(Passenger Door Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	PSCM(Power Steering Control Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	RCM(Restraint Control Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	RFA(Remote FunctionActuator)								
BETA-TEST	MONDEO-2.5L GASOLINE	SASM(Steering Angle Sensor Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	SRM(Speech Recognition Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	TCM(Transmission Control Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	TRM(Trailer Module)								
BETA-TEST	MONDEO-2.5L GASOLINE	VDM(Vehicle Dynamic Module)								
BETA-TEST	MONDEO-3.0L Duratec-ST	PCM(PowerTrain Control Module)								
BETA-TEST	MONDEO-3.0L Duratec-ST	ABS(Anti-Lock Brake System)								
BETA-TEST	MONDEO-3.0L Duratec-ST	ACM(Audio Control Module)								
BETA-TEST	MONDEO-3.0L Duratec-ST	CDP(Compact Disc Player)								
BETA-TEST	MONDEO-3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)								
BETA-TEST	MONDEO-3.0L Duratec-ST	GDM(Generic Display Module)								
BETA-TEST	MONDEO-3.0L Duratec-ST	GEM(Generic Electronic Module)								
BETA-TEST	MONDEO-3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)								
BETA-TEST	MONDEO-3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)								
BETA-TEST	MONDEO-3.0L Duratec-ST	NAV(Navigation System)								
BETA-TEST	MONDEO-3.0L Duratec-ST	RCM(Restraint Control Module)								
BETA-TEST	MONDEO-3.0L Duratec-ST	RETM(Rear Entertainment Module)								
BETA-TEST	MONDEO-3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)								
BETA-TEST	MONDEO-3.0L Duratec-ST	SRM(Speech Recognition Module)								
BETA-TEST	F-150 5.4L	PCM(PowerTrain Control Module)								
BETA-TEST	F-150 5.4L	4X4(4x4 Control Module)								
BETA-TEST	F-150 5.4L	ABS(Anti-Lock Brake System)								
BETA-TEST	F-150 5.4L	DSM(Driver Seat Module)								
BETA-TEST	F-150 5.4L	EATC(Electronic Automatic Temperature Control)								
BETA-TEST	F-150 5.4L	IC(Instrument Cluster)								
BETA-TEST	F-150 5.4L	PAM(Park Aid Module)								
BETA-TEST	F-150 5.4L	RCM(Restraint Control Module)								
BETA-TEST	F-150 5.4L	VSM(Vehicle Security Module)								
BETA-TEST	F-150 5.4L	PATS(Passive Anti Theft System)			V	V	V	V	V	

Model 1	Model 2	System 1	System 2	System 3	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PCM(PowerTrain Control Module)								
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	ABS(Anti-Lock Brake System)								
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	IC(Instrument Cluster)								
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PAM(Park Aid Module)								
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	RCM(Restraint Control Module)								
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	VSM(Vehicle Security Module)								
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture								V

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
Incode Calculator	~2010.05	All model			V																																														
ESCAPE	Up to 2004	SYSTEM SEARCH																																																	
ESCAPE	Up to 2004	PCM(PowerTrain Control Module)				V	V	V	V																																										
ESCAPE	Up to 2004	Immobilizer								V	V	V																																							
ESCAPE	Up to 2004	ABS(Anti-Lock Brake System)				V	V	V					V																																						
ESCAPE	Up to 2004	RCM(Restraint Control Module)				V	V	V	V				V																																						
ESCAPE	Up to 2004	GEM(Generic Electronic Module)				V	V	V	V				V																																						
ESCAPE	From 2004	SYSTEM SEARCH																																																	
ESCAPE	From 2004	PCM(PowerTrain Control Module)				V	V	V						V	V	V																																			
ESCAPE	From 2004	PATS(Passive anti theft system)															V	V																																	
ESCAPE	From 2004	ABS(Anti-Lock Brake System)				V	V	V	V																																										
ESCAPE	From 2004	ABS(Anti-Lock Brake System)				V	V																																												
ESCAPE	From 2004	RCM(Restraint Control Module)				V	V	V	V																																										
ESCAPE	From 2004	IC(Instrument Cluster)				V	V	V							V																																				
ESCAPE	From 2004	GEM(Generic Electronic Module)				V	V	V	V										V																																	
EXPLORER	2011 MY	3.5L TiCVT	SYSTEM SEARCH																																																
EXPLORER	2011 MY	3.5L TiCVT	PCM(Powertrain Control Module)			V	V	V												V	V	V	V	V	V	V																									
EXPLORER	2011 MY	3.5L TiCVT	ABS(Anti-Lock Brake System)			V	V	V	V						V					V								V	V																							
EXPLORER	2011 MY	3.5L TiCVT	ACM(Audio Control Module)			V	V	V							V					V										V																						
EXPLORER	2011 MY	3.5L TiCVT	APIM(Accessory Protocol Interface Module)			V	V	V												V											V																					
EXPLORER	2011 MY	3.5L TiCVT	BCM(Body Control Module)			V	V	V	V						V					V												V	V	V	V																	
EXPLORER	2011 MY	3.5L TiCVT	ATCM(All Terrain Control Module)			V	V	V							V					V																																
EXPLORER	2011 MY	3.5L TiCVT	C-CM(Cruise Control Module)			V	V	V							V					V															V	V																
EXPLORER	2011 MY	3.5L TiCVT	CLM(Column Lock Module)			V	V	V							V					V																																
EXPLORER	2011 MY	3.5L TiCVT	DCSM(Driver-Dual Climate Contol Seat Module)			V	V	V																																											
EXPLORER	2011 MY	3.5L TiCVT	DSM(Driver Seat Module)			V	V	V	V						V																																				
EXPLORER	2011 MY	3.5L TiCVT	DSP(Digital Signal Processing Module)			V	V	V							V					V																																
EXPLORER	2011 MY	3.5L TiCVT	FCIM(Front Controls Interface Module)			V	V	V							V					V																																
EXPLORER	2011 MY	3.5L TiCVT	FCDIM(Front Control/Display Interface Module)			V	V	V	V						V					V																																
EXPLORER	2011 MY	3.5L TiCVT	FLM(Front Lighting Control Module)			V	V	V							V					V																																
EXPLORER	2011 MY	3.5L TiCVT	GPSM(Global Positioning System Module)			V	V	V												V																																
EXPLORER	2011 MY	3.5L TiCVT	HUD(Head Up Display)			V	V	V							V					V																																
EXPLORER	2011 MY	3.5L TiCVT	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V						V					V																	V															
EXPLORER	2011 MY	3.5L TiCVT	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
EXPLORER	2011 MY	3.5L TiCVT	LTM(Liftgate/Trunk Module)			V	V	V																																											
EXPLORER	2011 MY	3.5L TiCVT	OCSM(Occupant Classification System Module)			V	V	V							V					V																																
EXPLORER	2011 MY	3.5L TiCVT	PAM(Parking Aid Module)			V	V	V							V					V																																
EXPLORER	2011 MY	3.5L TiCVT	PSCM(Power Steering Control Module)			V	V	V							V					V																																
EXPLORER	2011 MY	3.5L TiCVT	RCM(Restraint Control Module)			V	V	V							V					V																		V														
EXPLORER	2011 MY	3.5L TiCVT	RFA(Remote Function Actuator)			V	V	V	V						V					V																																
EXPLORER	2011 MY	3.5L TiCVT	RLCM-A(Rear Lighting Control Module A)			V	V	V												V																																
EXPLORER	2011 MY	3.5L TiCVT	SCCM(Streering Colume Control Module)			V	V	V							V					V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
EXPLORER	2011 MY	3.5L TiCVT	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V											V																																
EXPLORER	2011 MY	3.5L TiCVT	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V						V					V																																
EXPLORER	2011 MY	3.5L TiCVT	TPM(Tire Pressure Monitor)			V	V	V							V					V																																
EXPLORER	2010 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER	2010 MY	4.6L	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V		V	V	V	V																									
EXPLORER	2010 MY	4.6L	TCM(Transmission Control Module)			V	V	V							V	V							V	V	V	V												V													
EXPLORER	2010 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V						V																																				
EXPLORER	2010 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V												V	V											
EXPLORER	2010 MY	4.6L	ACM(Audio Control Module)			V	V	V							V					V																																
EXPLORER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																
EXPLORER	2010 MY	4.6L	GPSM(Global Positioning System Module)			V	V	V												V																																
EXPLORER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)			V	V	V																																											
EXPLORER	2010 MY	4.6L	DSM(Driver's Seat Module)			V	V	V							V																																				
EXPLORER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V							V				V													V																				
EXPLORER	2010 MY	4.6L	IC(Instrument Cluster)			V	V	V							V																									V												
EXPLORER	2010 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V							V																																				
EXPLORER	2010 MY	4.6L	PAM(Parking Aid Module)			V	V	V																																											
EXPLORER	2010 MY	4.6L	PRB(Power Running Board)			V	V	V	V						V																																				
EXPLORER	2010 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V						V																						V														
EXPLORER	2010 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V																																											
EXPLORER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V																																										
EXPLORER	2009 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER	2009 MY	4.6L	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V		V	V	V	V																									
EXPLORER	2009 MY	4.6L	TCM(Transmission Control Module)			V	V	V							V	V							V	V	V	V												V													
EXPLORER	2009 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V						V																																				
EXPLORER	2009 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V												V	V											
EXPLORER	2009 MY	4.6L	ACM(Audio Control Module)			V	V	V							V					V																																
EXPLORER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																
EXPLORER	2009 MY	4.6L	GPSM(Global Positioning System Module)			V	V	V												V																																
EXPLORER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)			V	V	V																																											
EXPLORER	2009 MY	4.6L	DSM(Driver's Seat Module)			V	V	V							V																																				
EXPLORER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V							V				V													V																				
EXPLORER	2009 MY	4.6L	IC(Instrument Cluster)			V	V	V							V																									V												
EXPLORER	2009 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V							V																																				
EXPLORER	2009 MY	4.6L	PAM(Parking Aid Module)			V	V	V																																											
EXPLORER	2009 MY	4.6L	PRB(Power Running Board)			V	V	V	V						V																																				
EXPLORER	2009 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V						V																						V														
EXPLORER	2009 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V																																											
EXPLORER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V																																										
EXPLORER	2008 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER	2008 MY	4.6L	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V		V	V	V	V																									
EXPLORER	2008 MY	4.6L	TCM(Transmission Control Module)			V	V	V							V	V							V	V	V	V												V													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
EXPLORER	2008 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V						V																																					
EXPLORER	2008 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V												V	V												
EXPLORER	2008 MY	4.6L	ACM(Audio Control Module)			V	V	V							V																																					
EXPLORER	2008 MY	4.6L	DSM(Driver's Seat Module)			V	V	V							V																																					
EXPLORER	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)			V	V	V	V						V																																					
EXPLORER	2008 MY	4.6L	GEM(Generic Electronic Module)			V	V	V							V				V													V																				
EXPLORER	2008 MY	4.6L	IC(Instrument Cluster)			V	V	V	V						V																											V										
EXPLORER	2008 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V							V																																					
EXPLORER	2008 MY	4.6L	PAM(Parking Aid Module)			V	V	V																																												
EXPLORER	2008 MY	4.6L	PRB(Power Running Board)			V	V	V	V						V																																					
EXPLORER	2008 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V						V																						V															
EXPLORER	2008 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V																																												
EXPLORER	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V																																											
EXPLORER	2007 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2007 MY	4.6L	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V		V	V	V	V																										
EXPLORER	2007 MY	4.6L	TCM(Transmission Control Module)			V	V	V							V	V							V	V	V	V												V														
EXPLORER	2007 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V						V																																					
EXPLORER	2007 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V												V	V												
EXPLORER	2007 MY	4.6L	ACM(Audio Control Module)			V	V	V							V																																					
EXPLORER	2007 MY	4.6L	DSM(Driver's Seat Module)			V	V	V							V																																					
EXPLORER	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)			V	V	V	V						V																																					
EXPLORER	2007 MY	4.6L	GEM(Generic Electronic Module)			V	V	V							V				V													V																				
EXPLORER	2007 MY	4.6L	IC(Instrument Cluster)			V	V	V	V						V																											V										
EXPLORER	2007 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V							V																																					
EXPLORER	2007 MY	4.6L	PAM(Parking Aid Module)			V	V	V																																												
EXPLORER	2007 MY	4.6L	PRB(Power Running Board)			V	V	V	V						V																																					
EXPLORER	2007 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V						V																						V															
EXPLORER	2007 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V																																												
EXPLORER	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V																																											
EXPLORER	2006 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2006 MY	4.6L	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V		V	V	V	V																										
EXPLORER	2006 MY	4.6L	TCM(Transmission Control Module)			V	V	V							V	V							V	V	V	V												V														
EXPLORER	2006 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V						V																																					
EXPLORER	2006 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V												V	V												
EXPLORER	2006 MY	4.6L	ACM(Audio Control Module)			V	V	V							V																																					
EXPLORER	2006 MY	4.6L	DSM(Driver's Seat Module)			V	V	V							V																																					
EXPLORER	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)			V	V	V	V						V																																					
EXPLORER	2006 MY	4.6L	GEM(Generic Electronic Module)			V	V	V							V				V													V																				
EXPLORER	2006 MY	4.6L	IC(Instrument Cluster)			V	V	V	V						V																											V										
EXPLORER	2006 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V							V																																					
EXPLORER	2006 MY	4.6L	PAM(Parking Aid Module)			V	V	V																																												
EXPLORER	2006 MY	4.6L	PRB(Power Running Board)			V	V	V	V						V																																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
EXPLORER	2006 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V						V																						V															
EXPLORER	2006 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V																																												
EXPLORER	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V																																											
EXPLORER	2000 MY	SYSTEM SEARCH																																																	
EXPLORER	2000 MY	PCM(PowerTrain Control Module)				V	V	V	V																																										
EXPLORER	2000 MY	ABS(Anti-Lock Brake System)				V	V	V					V																																						
EXPLORER	2000 MY	RCM(Restraint Control Module)				V	V	V	V				V																																						
EXPLORER	2000 MY	RIM(Remote Immobilizer Module)				V	V	V	V				V																																						
EXPLORER	2000 MY	GEM(Generic Electronic Module)				V	V	V	V				V																																						
EXPLORER	2000 MY	PAM(Parking Aid Module)				V	V	V					V																																						
EXPLORER	1999 MY	SYSTEM SEARCH																																																	
EXPLORER	1999 MY	PCM(PowerTrain Control Module)				V	V	V	V																																										
EXPLORER	1999 MY	ABS(Anti-Lock Brake System)				V	V	V					V																																						
EXPLORER	1999 MY	RCM(Restraint Control Module)				V	V	V	V				V																																						
EXPLORER	1999 MY	RIM(Remote Immobilizer Module)				V	V	V	V				V																																						
EXPLORER	1999 MY	PAM(Parking Aid Module)				V	V	V					V																																						
EXPLORER	1998 MY	SYSTEM SEARCH																																																	
EXPLORER	1998 MY	PCM(PowerTrain Control Module)				V	V	V	V																																										
EXPLORER	1998 MY	ABS(Anti-Lock Brake System)				V	V	V					V																																						
EXPLORER	1998 MY	RCM(Restraint Control Module)				V	V	V	V				V																																						
EXPLORER	1998 MY	RIM(Remote Immobilizer Module)				V	V	V	V				V																																						
EXPLORER	1997 MY	SYSTEM SEARCH																																																	
EXPLORER	1997 MY	PCM(PowerTrain Control Module)				V	V	V	V																																										
EXPLORER	1997 MY	ABS(Anti-Lock Brake System)				V	V	V					V																																						
EXPLORER	1997 MY	RCM(Restraint Control Module)				V	V	V					V																																						
EXPLORER	1997 MY	RIM(Remote Immobilizer Module)				V	V	V	V				V																																						
EXPLORER SPORT-TRAC	2010 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER SPORT-TRAC	2010 MY	4.6L	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V		V	V	V	V																									
EXPLORER SPORT-TRAC	2010 MY	4.6L	TCM(Transmission Control Module)			V	V	V							V	V							V	V	V	V												V													
EXPLORER SPORT-TRAC	2010 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V						V																																				
EXPLORER SPORT-TRAC	2010 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V												V	V											
EXPLORER SPORT-TRAC	2010 MY	4.6L	ACM(Audio Control Module)			V	V	V							V					V																															
EXPLORER SPORT-TRAC	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																															
EXPLORER SPORT-TRAC	2010 MY	4.6L	GPSM(Global Positioning System Module)			V	V	V												V																															
EXPLORER SPORT-TRAC	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)			V	V	V																																											
EXPLORER SPORT-TRAC	2010 MY	4.6L	DSM(Driver's Seat Module)			V	V	V							V																																				
EXPLORER SPORT-TRAC	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V							V				V													V																			
EXPLORER SPORT-TRAC	2010 MY	4.6L	IC(Instrument Cluster)			V	V	V							V																									V											
EXPLORER SPORT-TRAC	2010 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V							V																																				
EXPLORER SPORT-TRAC	2010 MY	4.6L	PAM(Parking Aid Module)			V	V	V																																											
EXPLORER SPORT-TRAC	2010 MY	4.6L	PRB(Power Running Board)			V	V	V	V						V																																				
EXPLORER SPORT-TRAC	2010 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V						V																						V														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
EXPLORER SPORT-TRAC	2010 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V																																												
EXPLORER SPORT-TRAC	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V																																											
EXPLORER SPORT-TRAC	2009 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V		V	V	V	V																										
EXPLORER SPORT-TRAC	2009 MY	4.6L	TCM(Transmission Control Module)			V	V	V							V	V							V	V	V	V												V														
EXPLORER SPORT-TRAC	2009 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V						V																																					
EXPLORER SPORT-TRAC	2009 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V												V	V												
EXPLORER SPORT-TRAC	2009 MY	4.6L	ACM(Audio Control Module)			V	V	V							V					V																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	GPSM(Global Positioning System Module)			V	V	V												V																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)			V	V	V																																												
EXPLORER SPORT-TRAC	2009 MY	4.6L	DSM(Driver's Seat Module)			V	V	V							V																																					
EXPLORER SPORT-TRAC	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V							V				V													V																				
EXPLORER SPORT-TRAC	2009 MY	4.6L	IC(Instrument Cluster)			V	V	V							V																										V											
EXPLORER SPORT-TRAC	2009 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V							V																																					
EXPLORER SPORT-TRAC	2009 MY	4.6L	PAM(Parking Aid Module)			V	V	V																																												
EXPLORER SPORT-TRAC	2009 MY	4.6L	PRB(Power Running Board)			V	V	V	V						V																																					
EXPLORER SPORT-TRAC	2009 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V						V																						V															
EXPLORER SPORT-TRAC	2009 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V																																												
EXPLORER SPORT-TRAC	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V																																											
EXPLORER SPORT-TRAC	2008 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V		V	V	V	V																										
EXPLORER SPORT-TRAC	2008 MY	4.6L	TCM(Transmission Control Module)			V	V	V							V	V							V	V	V	V												V														
EXPLORER SPORT-TRAC	2008 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V						V																																					
EXPLORER SPORT-TRAC	2008 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V												V	V												
EXPLORER SPORT-TRAC	2008 MY	4.6L	ACM(Audio Control Module)			V	V	V							V																																					
EXPLORER SPORT-TRAC	2008 MY	4.6L	DSM(Driver's Seat Module)			V	V	V							V																																					
EXPLORER SPORT-TRAC	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)			V	V	V	V						V																																					
EXPLORER SPORT-TRAC	2008 MY	4.6L	GEM(Generic Electronic Module)			V	V	V							V				V													V																				
EXPLORER SPORT-TRAC	2008 MY	4.6L	IC(Instrument Cluster)			V	V	V	V						V																											V										
EXPLORER SPORT-TRAC	2008 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V							V																																					
EXPLORER SPORT-TRAC	2008 MY	4.6L	PAM(Parking Aid Module)			V	V	V																																												
EXPLORER SPORT-TRAC	2008 MY	4.6L	PRB(Power Running Board)			V	V	V	V						V																																					
EXPLORER SPORT-TRAC	2008 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V						V																						V															
EXPLORER SPORT-TRAC	2008 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V																																												
EXPLORER SPORT-TRAC	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V																																											
EXPLORER SPORT-TRAC	2007 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V		V	V	V	V																										
EXPLORER SPORT-TRAC	2007 MY	4.6L	TCM(Transmission Control Module)			V	V	V							V	V							V	V	V	V												V														
EXPLORER SPORT-TRAC	2007 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V						V																																					
EXPLORER SPORT-TRAC	2007 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V												V	V												
EXPLORER SPORT-TRAC	2007 MY	4.6L	ACM(Audio Control Module)			V	V	V							V																																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
EXPLORER SPORT-TRAC	2007 MY	4.6L	DSM(Driver's Seat Module)			V	V	V							V																																					
EXPLORER SPORT-TRAC	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)			V	V	V	V						V																																					
EXPLORER SPORT-TRAC	2007 MY	4.6L	GEM(Generic Electronic Module)			V	V	V							V				V													V																				
EXPLORER SPORT-TRAC	2007 MY	4.6L	IC(Instrument Cluster)			V	V	V	V						V																											V										
EXPLORER SPORT-TRAC	2007 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V							V																																					
EXPLORER SPORT-TRAC	2007 MY	4.6L	PAM(Parking Aid Module)			V	V	V																																												
EXPLORER SPORT-TRAC	2007 MY	4.6L	PRB(Power Running Board)			V	V	V	V						V																																					
EXPLORER SPORT-TRAC	2007 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V						V																						V															
EXPLORER SPORT-TRAC	2007 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V																																												
EXPLORER SPORT-TRAC	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V																																											
EXPLORER SPORT-TRAC	2006 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V		V	V	V	V																										
EXPLORER SPORT-TRAC	2006 MY	4.6L	TCM(Transmission Control Module)			V	V	V							V	V							V	V	V	V												V														
EXPLORER SPORT-TRAC	2006 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V						V																																					
EXPLORER SPORT-TRAC	2006 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V												V	V												
EXPLORER SPORT-TRAC	2006 MY	4.6L	ACM(Audio Control Module)			V	V	V							V																																					
EXPLORER SPORT-TRAC	2006 MY	4.6L	DSM(Driver's Seat Module)			V	V	V							V																																					
EXPLORER SPORT-TRAC	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)			V	V	V	V						V																																					
EXPLORER SPORT-TRAC	2006 MY	4.6L	GEM(Generic Electronic Module)			V	V	V							V				V													V																				
EXPLORER SPORT-TRAC	2006 MY	4.6L	IC(Instrument Cluster)			V	V	V	V						V																											V										
EXPLORER SPORT-TRAC	2006 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V							V																																					
EXPLORER SPORT-TRAC	2006 MY	4.6L	PAM(Parking Aid Module)			V	V	V																																												
EXPLORER SPORT-TRAC	2006 MY	4.6L	PRB(Power Running Board)			V	V	V	V						V																																					
EXPLORER SPORT-TRAC	2006 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V						V																						V															
EXPLORER SPORT-TRAC	2006 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V																																												
EXPLORER SPORT-TRAC	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V																																											
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)			V	V	V												V																							V	V	V	V						
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V												V																											V	V	V	V	V
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V					V							V																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V												V																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)			V	V	V							V					V																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V												V																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V							V					V																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V												V																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V												V																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)			V	V	V							V					V																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)			V	V	V							V	V				V	V																						V									
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V												V																											V	V	V	V	V

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V					V							V																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	BCM(Body Control Module)			V	V	V							V					V																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)			V	V	V												V																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	GPSM(Global Positioning System Module)			V	V	V							V					V																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)			V	V	V												V																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V												V																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)			V	V	V							V					V																															
ECOSPORT	1.5L	DURATEC VCT	SYSTEM SEARCH																																																
ECOSPORT	1.5L	DURATEC VCT	PCM(Powertrain Control Module)			V	V	V												V																								V							
ECOSPORT	1.5L	DURATEC VCT	ABS(Anti-Lock Brake System)			V	V	V												V																											V	V	V	V	V
ECOSPORT	1.5L	DURATEC VCT	ACM(Audio Control Module)			V	V	V					V							V																															
ECOSPORT	1.5L	DURATEC VCT	APIM(Accessory Protocol Interface Module)			V	V	V												V																															
ECOSPORT	1.5L	DURATEC VCT	BCMii(Body Control Module)			V	V	V							V					V																															
ECOSPORT	1.5L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)			V	V	V												V																															
ECOSPORT	1.5L	DURATEC VCT	GPSM(Global Positioning System Module)			V	V	V							V					V																															
ECOSPORT	1.5L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																															
ECOSPORT	1.5L	DURATEC VCT	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																															
ECOSPORT	1.5L	DURATEC VCT	PSCM(Power Steering Control Module)			V	V	V												V																															
ECOSPORT	1.5L	DURATEC VCT	RCM(Restraint Control Module)			V	V	V												V																															
ECOSPORT	1.5L	DURATEC VCT	RFA(Remote Function Actuator)			V	V	V							V					V																															
ECOSPORT	1.5L	DURATEC VCT	TCM(Transmission Control Module)			V	V	V												V																															
FIESTA	1.25L	DURATEC 16V	SYSTEM SEARCH																																																
FIESTA	1.25L	DURATEC 16V	PCM(PowerTrain Control Module)			V	V	V							V	V				V																															
FIESTA	1.25L	DURATEC 16V	ABS(Anti-Lock Brake System)			V	V	V												V																															
FIESTA	1.25L	DURATEC 16V	ACM(Audio Control Module)			V	V	V							V					V																															
FIESTA	1.25L	DURATEC 16V	APIM(Accessory Protocol Interface Module)			V	V	V												V																															
FIESTA	1.25L	DURATEC 16V	BCMii(Body Control Module)			V	V	V	V						V					V																															
FIESTA	1.25L	DURATEC 16V	DDM(Driver's Door Module)			V	V	V												V																															
FIESTA	1.25L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)			V	V	V	V											V																															
FIESTA	1.25L	DURATEC 16V	FDSM(Front Distance Sensing Module)			V	V	V												V																															
FIESTA	1.25L	DURATEC 16V	GPSM(Global Positioning System Module)			V	V	V							V					V																															
FIESTA	1.25L	DURATEC 16V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V											V																															
FIESTA	1.25L	DURATEC 16V	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																															
FIESTA	1.25L	DURATEC 16V	PDM(Passenger's Door Module)			V	V	V							V					V																															
FIESTA	1.25L	DURATEC 16V	PSCM(Power Steering Control Module)			V	V	V							V					V																															
FIESTA	1.25L	DURATEC 16V	RCM(Restraint Control Module)			V	V	V							V					V																															
FIESTA	1.25L	DURATEC 16V	RFA(Remote Function Actuator)			V	V	V												V																															
FIESTA	1.4L GASOLINE	SYSTEM SEARCH																																																	
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)				V	V	V							V	V					V																															
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)				V	V	V							V					V																								V							

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)				V	V	V	V																																											
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)				V	V	V																																												
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)				V	V	V												V																																
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V	V																																											
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V	V				V																																							
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V												V																																
FIESTA	1.4L GASOLINE	APIM(Accessory Protocol Interface Module)				V	V	V												V																																
FIESTA	1.4L GASOLINE	PSCM(Power Steering Control Module)				V	V	V							V					V																																
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)				V	V	V																																												
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)				V	V	V												V																	V															
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)				V	V	V	V						V																																					
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)				V	V	V												V																																
FIESTA	1.4L GASOLINE	GEM(Generic Electronic Module)				V	V	V	V										V																																	
FIESTA	1.4L GASOLINE	BCMii(Body Control Module)				V	V	V	V						V					V																																
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)				V	V	V												V																																
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)				V	V	V	V						V					V																																
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)				V	V	V	V											V																																
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)				V	V	V												V																																
FIESTA	1.4L GASOLINE	RFA(Remote Function Actuator)				V	V	V												V																																
FIESTA	1.4L GASOLINE	SRM(Speech Recognition Module)				V	V	V							V					V																																
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)				V	V	V							V					V																																
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)				V	V	V												V																																
FIESTA	1.4L GASOLINE	DDM(Driver's Door Module)				V	V	V												V																																
FIESTA	1.4L GASOLINE	FDSM(Front Distance Sensing Module)				V	V	V												V																																
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)				V	V	V	V						V					V																																
FIESTA	1.4L GASOLINE	GPSM(Global Positioning System Module)				V	V	V												V																																
FIESTA	1.4L GASOLINE	PDM(Passenger's Door Module)				V	V	V												V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V							V	V				V																						V	V								
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V	V					V	V	V				V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)			V	V	V																																											
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V												V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V	V																																										
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)			V	V	V	V						V																																				
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)			V	V	V	V						V					V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)			V	V	V	V						V																																				
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V							V					V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)			V	V	V							V					V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V						V					V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V						V					V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)			V	V	V							V					V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)			V	V	V												V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)			V	V	V																																												
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)			V	V	V							V					V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)			V	V	V												V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)			V	V	V												V																							V								
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)			V	V	V												V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)			V	V	V					V							V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)			V	V	V	V						V					V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)			V	V	V	V											V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)			V	V	V							V					V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)			V	V	V												V																	V														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)			V	V	V												V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)			V	V	V												V																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V						V					V																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)			V	V	V												V																							V	V							
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)			V	V	V												V																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)			V	V	V					V							V																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)			V	V	V	V						V					V																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)			V	V	V	V											V																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)			V	V	V							V					V																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)			V	V	V												V																	V														
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)			V	V	V												V																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)			V	V	V												V																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V						V					V																																
FIESTA	1.5L	TiVCT	SYSTEM SEARCH																																																
FIESTA	1.5L	TiVCT	PCM(PowerTrain Control Module)			V	V	V	V					V	V	V				V																																
FIESTA	1.5L	TiVCT	ABS(Anti-Lock Brake System)			V	V	V												V																																
FIESTA	1.5L	TiVCT	ACM(Audio Control Module)			V	V	V					V							V																																
FIESTA	1.5L	TiVCT	BCMii(Body Control Module)			V	V	V	V						V					V																																
FIESTA	1.5L	TiVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V											V																																
FIESTA	1.5L	TiVCT	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
FIESTA	1.5L	TiVCT	PSCM(Power Steering Control Module)			V	V	V							V					V																																
FIESTA	1.5L	TiVCT	RCM(Retraint Control Module)			V	V	V												V																	V														
FIESTA	1.5L	TiVCT	RFA(Remote Function Actuator)			V	V	V												V																																
FIESTA	1.5L	TiVCT	SRM(Speech Recognition Module)			V	V	V												V																																
FIESTA	1.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V											V																																
FIESTA	1.5L	TiVCT	TCM(Transmission Control Module)			V	V	V							V	V				V																																
FIESTA	1.6L GASOLINE	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)				V	V	V						V	V	V				V	V		V	V	V	V																									
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)				V	V	V							V					V																									V							
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)				V	V	V	V																																											
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)				V	V	V																																												
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)				V	V	V												V																																
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V	V																																											
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V	V				V																																							
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V												V																																
FIESTA	1.6L GASOLINE	PSCM(Power Steering Control Module)				V	V	V							V					V																																
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)				V	V	V																																												
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)				V	V	V												V																	V															
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)				V	V	V	V						V																																					
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)				V	V	V												V																																
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)				V	V	V	V						V																																					
FIESTA	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)				V	V	V	V						V																																					
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)				V	V	V	V						V																																					
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)				V	V	V	V										V																																	
FIESTA	1.6L GASOLINE	BCMii(Body Control Module)				V	V	V	V						V					V																																
FIESTA	1.6L GASOLINE	FCDIM(Front Control/Display Interface Module)				V	V	V												V																																
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)				V	V	V							V					V																																
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)				V	V	V																																												
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)				V	V	V							V					V																																
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)				V	V	V																																												
FIESTA	1.6L ZETEC ROCAM	SYSTEM SEARCH																																																	
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)				V	V	V	V					V	V	V				V	V																															
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)				V	V	V	V																																											
FIESTA	1.6L ZETEC ROCAM	ABS(Anti-Lock Brake System)				V	V	V	V																																											
FIESTA	1.6L ZETEC ROCAM	IC(Instrument Cluster)				V	V	V	V						V																																					
FIESTA	1.6L ZETEC ROCAM	RCM(Restraint Control Module)				V	V	V																																												
FIESTA	1.6L ZETEC ROCAM	RKE(Remote Keyless Entry)				V	V	V											V																																	
FIESTA	1.6L ZETEC ROCAM	TCM(Transmission Control Module)				V	V	V													V																																
FIESTA	1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																																	
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)				V	V	V	V																																											
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)				V	V	V	V																																											
FIESTA	1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)				V	V	V																																												
FIESTA	1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)				V	V	V																																												
FIESTA	1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)				V	V	V	V																																											
FIESTA	2.0L GASOLINE	SYSTEM SEARCH																																																	
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)				V	V	V	V					V	V	V				V	V																															
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)				V	V	V	V																																											
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)				V	V	V							V					V																									V							
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V	V				V																																							

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V												V																																
FIESTA	2.0L GASOLINE	ACM(Audio Control Module)				V	V	V																																												
FIESTA	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)				V	V	V																																												
FIESTA	2.0L GASOLINE	GEM(Generic Electronic Module)				V	V	V	V																																											
FIESTA	2.0L GASOLINE	IC(Instrument Cluster)				V	V	V	V						V																																					
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)				V	V	V																																												
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)				V	V	V												V																																
FIESTA	2.0L GASOLINE	RCM(Restraint Control Module)				V	V																																													
FIESTA	2.0L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																		
FIGO	1.4L DIESEL	SYSTEM SEARCH																																																		
FIGO	1.4L DIESEL	PCM(Powertrain Control Module)				V	V	V							V	V				V	V																															
FIGO	1.4L DIESEL	ABS(Anti-Lock Brake System)				V	V	V	V																																											
FIGO	1.4L DIESEL	IC(Instrument Cluster)				V	V	V	V						V																											V										
FIGO	1.4L DIESEL	RCM(Restraint Control Module)				V	V	V																																												
FIGO	1.6L	DURATEC 16V	SYSTEM SEARCH																																																	
FIGO	1.6L	DURATEC 16V	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V																															
FIGO	1.6L	DURATEC 16V	ABS(Anti-Lock Brake System)			V	V	V	V																																											
FIGO	1.6L	DURATEC 16V	GEM(Generic Electronic Module)			V	V	V	V																																											
FIGO	1.6L	DURATEC 16V	IC(Instrument Cluster)			V	V	V	V						V																											V										
FIGO	1.6L	DURATEC 16V	RCM(Restraint Control Module)			V	V	V																																												
FIGO	1.6L	DURATEC 16V	TCM(Transmission Control Module)			V	V	V																																												
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V												V																							V	V	V	V						
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V												V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V	V						V					V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)			V	V	V												V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V												V									V																							
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)			V	V	V												V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)			V	V	V							V					V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)			V	V	V												V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V	V						V					V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V												V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM(Front Distance Sensing Module)			V	V	V												V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V						V					V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V							V					V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)			V	V	V							V					V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)			V	V													V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)			V	V								V																																				
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V												V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)			V	V	V												V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V												V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V												V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)			V	V	V							V					V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)			V	V	V							V					V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)			V	V								V					V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V						V					V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V						V					V																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)			V	V	V	V											V																																
FOCUS	1.4L	DURATEC 16V	SYSTEM SEARCH																																																
FOCUS	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)			V	V	V												V																																
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)			V	V	V	V				V																																							
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)			V	V	V	V																		V																										
FOCUS	1.4L	DURATEC 16V	ACM(Audio Control Module)			V	V	V																																												
FOCUS	1.4L	DURATEC 16V	CDP(Compact Disc Player)			V	V	V																																												
FOCUS	1.4L	DURATEC 16V	D_DCU(Driver Door Control Unit)			V	V	V	V						V																																					
FOCUS	1.4L	DURATEC 16V	GDM(Generic Display Module)			V	V	V																																												
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)			V	V	V	V				V																																							
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)			V	V	V	V						V																																					
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)			V	V	V																																												
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)			V	V	V							V					V																																
FOCUS	1.4L	DURATEC 16V	EATC(Electronic Automatic Temperature Control)			V	V	V	V																																											
FOCUS	1.4L	DURATEC 16V	FFH(Fuel Fired Coolant Heating Module)			V	V	V																																												
FOCUS	1.4L	DURATEC 16V	IC(Instrument Cluster)			V	V	V	V						V																											V											
FOCUS	1.4L	DURATEC 16V	NAV(Navigation System)			V	V	V																																												
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)			V	V	V																																												
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)			V	V	V												V																																
FOCUS	1.4L	DURATEC 16V	PDM(Passenger's Door Module)			V	V	V							V																																					
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)			V	V	V					V																																							
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)			V	V	V																													V															
FOCUS	1.4L	DURATEC 16V	RKE(Remote Keyless Entry)			V	V	V																																												
FOCUS	1.4L	DURATEC 16V	CSM(Central Security Module)			V	V	V	V				V																																							
FOCUS	1.4L	DURATEC 16V	HEC(Hybrid Electrical Cluster)			V	V	V																																												
FOCUS	1.4L	DURATEC 16V	MC(Message Center)			V	V		V				V																																							
FOCUS	1.4L	DURATEC 16V	RETM(Rear Entertainment Module)			V	V	V																																												
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)			V	V	V							V	V				V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TCM(Transmission Control Module)			V	V	V												V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)			V	V	V												V																											V	V	V	V	V
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)			V	V	V					V							V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)			V	V	V												V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)			V	V	V												V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body control module)			V	V	V							V					V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	CCMii(Cruise Control Module)			V	V	V							V					V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	DDM(Driver's Door Module)			V	V	V							V					V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	DDM(Driver's Door Module)			V	V	V																																											
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FCIM(Front Controls Interface Module)			V	V	V												V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FDSM(Front Distance Sensing Module)			V	V	V												V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FCDIM(Front Control/Display Interface Module)			V	V	V							V					V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	GPSM(Global Positioning System Module)			V	V	V												V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	HCM(Headlamp Control Module)			V	V	V							V					V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	HVAC(Heating Ventilation Air Conditioning)			V	V	V							V					V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	IPM-A(Image Processing Module A)			V	V	V												V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PAM(Parking Aid Module)			V	V	V							V					V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PDM(Passenger's Door Module)			V	V	V												V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PSCM(Power Steering Control Module)			V	V	V												V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	RCM(Restraint Control Module)			V	V	V							V					V																	V														
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	RFA(Remote Function Actuator)			V	V	V												V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SASM(Steering Angle Sensor Module)			V	V	V												V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V						V					V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V						V					V																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	TRM(Trailer Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	ZETEC SE	SYSTEM SEARCH																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	PCM(PowerTrain Control Module)			V	V	V	V																																											
FOCUS	1.6L GASOLINE	ZETEC SE	ABS(Anti-Lock Brake System)			V	V	V	V																																											
FOCUS	1.6L GASOLINE	ZETEC SE	EATC(Electronic Automatic Temperature Control)			V	V	V	V																																											
FOCUS	1.6L GASOLINE	ZETEC SE	GEM(Generic Electronic Module)			V	V	V	V										V																																	
FOCUS	1.6L GASOLINE	ZETEC SE	RCM(Restraint Control Module)			V	V	V	V																																											
FOCUS	1.6L GASOLINE	ZETEC SE	MC(Message Center)			V	V	V	V																																											
FOCUS	1.6L GASOLINE	DURATEC	SYSTEM SEARCH																																																	
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)			V	V	V												V																																	
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)			V	V	V	V																																											
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)			V	V	V	V				V																																							
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)			V	V	V	V																		V																										
FOCUS	1.6L GASOLINE	DURATEC	ACM(Audio Control Module)			V	V	V																																												
FOCUS	1.6L GASOLINE	DURATEC	CDP(Compact Disc Player)			V	V	V																																												
FOCUS	1.6L GASOLINE	DURATEC	D_DCU(Driver Door Control Unit)			V	V	V	V						V																																					
FOCUS	1.6L GASOLINE	DURATEC	GDM(Generic Display Module)			V	V	V																																												
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)			V	V	V	V				V																																							
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)			V	V	V	V						V																																					
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)			V	V	V																																												
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)			V	V	V							V					V																																	
FOCUS	1.6L GASOLINE	DURATEC	EATC(Electronic Automatic Temperature Control)			V	V	V	V																																											
FOCUS	1.6L GASOLINE	DURATEC	FFH(Fuel Fired Coolant Heating Module)			V	V	V																																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FOCUS	1.6L GASOLINE	DURATEC	IC(Instrument Cluster)			V	V	V	V						V																											V										
FOCUS	1.6L GASOLINE	DURATEC	NAV(Navigation System)			V	V	V																																												
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)			V	V	V																																												
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	DURATEC	PDM(Passenger's Door Module)			V	V	V							V																																					
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)			V	V	V					V																																							
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)			V	V	V																													V															
FOCUS	1.6L GASOLINE	DURATEC	RKE(Remote Keyless Entry)			V	V	V																																												
FOCUS	1.6L GASOLINE	DURATEC	RL_DCU(Rear Left Door Control Unit)			V	V	V																																												
FOCUS	1.6L GASOLINE	DURATEC	RR_DCU(Rear Right Door Control Unit)			V	V	V																																												
FOCUS	1.6L GASOLINE	DURATEC	CSM(Central Security Module)			V	V	V	V				V																																							
FOCUS	1.6L GASOLINE	DURATEC	HEC(Hybrid Electrical Cluster)			V	V	V																																												
FOCUS	1.6L GASOLINE	DURATEC	MC(Message Center)			V	V		V				V																																							
FOCUS	1.6L GASOLINE	DURATEC	PATS(Passive Anti Theft System)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SYSTEM SEARCH																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)			V	V	V												V																								V								
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TCM(Transmission Control Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)			V	V	V	V				V																																							
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)			V	V	V	V																	V																										
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)			V	V	V																																												
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)			V	V	V					V							V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	AHCM(Auxiliary Heater Control Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	BCMii(Body Control Module)			V	V	V												V											V																						
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	CCMii(Cruise Control Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DDM(Driver's Door Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DSP(Digital Signal Processing Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCIM(Front Controls Interface Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FDSM(Front Distance Sensing Module)			V	V													V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V						V					V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HCM(Headlamp Control Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-A(Image Processing Module A)			V	V													V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-B(Image Processing Module B)			V	V	V																																												
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPC(Instrument Panel Control Module)			V	V	V	V											V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)			V	V	V																																												
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)			V	V	V							V																																					
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PSCM(Power Steering Control Module)			V	V	V												V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)			V	V	V																													V														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RFA(Remote Function Actuator)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SASM(Steering Angle Sensor Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SRM(Speech Recognition Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TRM(Trailer Module)			V	V	V												V																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PATS(Passive Anti Theft System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V							V	V				V																							V									
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V												V																							V		V							
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V	V																	V																										
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)			V	V	V	V																																											
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GDM(Generic Display Module)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)			V	V	V	V																																											
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	NAV(Navigation System)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V																													V														
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)			V	V	V																																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)			V	V	V							V					V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Condtioning)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)			V	V								V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)			V	V								V																																				
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)			V	V								V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)			V	V								V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)			V	V	V												V																							V									
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)			V	V	V												V																											V	V	V	V	V
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)			V	V	V					V							V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Condtioning)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)			V	V								V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)			V	V	V							V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)			V	V	V							V					V																	V														
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)			V	V	V												V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)			V	V								V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)			V	V								V					V																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)			V	V	V												V																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)			V	V	V	V					V	V	V				V	V																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)			V	V	V	V																																											
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)			V	V	V	V																		V																									
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)			V	V	V	V				V																																							

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CMR(Camera Module Rear)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CDP(Compact Disc Player)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	D_DCU(Driver Door Control Unit)			V	V	V	V																																											
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPB(Electronic Parking Brake)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPS(Electronic Power Steering)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GDM(Generic Display Module)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)			V	V	V	V				V																																							
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)			V	V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HCM(Headlamp Control Module)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	IC(Instrument Cluster)			V	V	V	V																																											
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	NAV(Navigation System)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PDM(Passenger's Door Module)			V	V	V	V																																											
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)			V	V	V					V																																							
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)			V	V	V																													V															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RETM(Rear Entertainment Module)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RKE(Remote Keyless Entry)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CSM(Central Security Module)			V	V	V	V				V																																							
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)			V	V	V																																												
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	MC(Message Center)			V	V		V				V																																							
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SYSTEM SEARCH																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)			V	V	V	V					V	V	V				V	V																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)			V	V	V	V																																											
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	TCM(Transmission Control Module)			V	V	V																																												
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)			V	V	V	V																		V																										
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)			V	V	V	V				V																																							
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ACM(Audio Control Module)			V	V	V																																												
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CMR(Camera Module Rear)			V	V	V																																												
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CDP(Compact Disc Player)			V	V	V																																												
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CSM(Central Security Module)			V	V	V	V				V																																							
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	D_DCU(Driver Door Control Unit)			V	V	V	V																																											
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)			V	V	V																																												
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPB(Electronic Parking Brake)			V	V	V																																												
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPS(Electronic Power Steering)			V	V	V																																												
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)			V	V	V																																												
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GDM(Generic Display Module)			V	V	V																																												
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)			V	V	V	V				V																																							

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)			V	V	V	V																																										
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)			V	V	V																																										
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HCM(Headlamp Control Module)			V	V	V																																										
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	IC(Instrument Cluster)			V	V	V	V																																									
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)			V	V		V				V																																					
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)			V	V	V	V																																									
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	NAV(Navigation System)			V	V	V																																										
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PAM(Parking Aid Module)			V	V	V																																										
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PDM(Passenger's Door Module)			V	V	V	V																																									
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)			V	V	V					V																																					
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)			V	V	V																													V													
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RETM(Rear Entertainment Module)			V	V	V																																										
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RKE(Remote Keyless Entry)			V	V	V																																										
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SRM(Speech Recognition Module)			V	V	V																																										
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SYSTEM SEARCH																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)			V	V	V												V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V						V	V				V																								V							
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TCM(Transmission Control Module)			V	V	V												V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V				V																																						
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V																	V																									
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)			V	V	V												V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)			V	V	V																																										
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)			V	V	V					V							V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	AHCM(Auxiliary Heater Control Module)			V	V	V												V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	BCMii(Body Control Module)			V	V	V												V											V																				
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	CCMii(Cruise Control Module)			V	V	V												V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DDM(Driver's Door Module)			V	V	V												V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DSP(Digital Signal Processing Module)			V	V	V												V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCIM(Front Controls Interface Module)			V	V	V												V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FDSM(Front Distance Sensing Module)			V	V													V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V						V					V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HCM(Headlamp Control Module)			V	V	V												V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-A(Image Processing Module A)			V	V													V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-B(Image Processing Module B)			V	V	V																																											
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V											V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)			V	V	V																																											
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)			V	V	V												V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)			V	V	V												V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)			V	V	V							V																																				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PSCM(Power Steering Control Module)			V	V	V												V																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)			V	V	V												V																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)			V	V	V																													V														
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RFA(Remote Function Actuator)			V	V	V												V																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SASM(Steering Angle Sensor Module)			V	V	V												V																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SRM(Speech Recognition Module)			V	V	V												V																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V												V																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V												V																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TRM(Trailer Module)			V	V	V												V																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PATS(Passive Anti Theft System)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	SYSTEM SEARCH																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PCM(PowerTrain Control Module)		V	V	V	V						V	V				V																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	TCM(Transmission Control Module)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ACM(Audio Control Module)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ABS(Anti-Lock Brake System)		V	V	V	V																	V													V													
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CDP(Compact Disc Player)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CMR(Camera Module Rear)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	D_DCU(Driver Door Control Unit)		V	V	V	V																																											
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ETC(Electronic Automatic Temperature Control)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	EPS(Electronic Power Steering)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FACM(Fuel Additive Control Module)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FFH(Fuel Fired Coolant Heating Module)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	GEM(Generic Electronic Module)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	HCM(Headlamp Control Module)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	IC(Instrument Cluster)		V	V	V	V																																											
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PDM(Passenger's Door Module)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PAM(Parking Aid Module)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RCM(Restraint Control Module)		V	V	V																													V															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RETM(Rear Entertainment Module)		V	V	V																																												
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RKE(Remote Keyless Entry)		V	V	V							V																																					
FOCUS	2.5L GASOLINE	SYSTEM SEARCH																																																		
FOCUS	2.5L GASOLINE	PCM(PowerTrain Control Module)				V	V	V						V	V	V																																				
FOCUS	2.5L GASOLINE	TCM(Transmission Control Module)				V	V	V																																													
FOCUS	2.5L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V	V																																												
FOCUS	2.5L GASOLINE	EPS(Electronic Power Steering)				V	V	V																																													
FOCUS	2.5L GASOLINE	RCM(Restraint Control Module)				V	V	V																																													
FOCUS	2.5L GASOLINE	GEM(Generic Electronic Module)				V	V	V																																													
FOCUS	2.5L GASOLINE	IC(Instrument Cluster)				V	V	V	V																																												
FOCUS	2.5L GASOLINE	DDM(Driver's Door Module)				V	V	V							V																																					
FOCUS	2.5L GASOLINE	PDM(Passenger's Door Module)				V	V	V							V																																					
FOCUS	2.5L GASOLINE	MC(Message Center)				V	V	V	V																																											
FOCUS	2.5L GASOLINE	ACM(Audio Control Module)				V	V	V							V																																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FOCUS C-MAX	1.6L DIESEL	SYSTEM SEARCH																																																		
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)				V	V	V							V	V				V																							V								
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)				V	V	V												V																							V		V						
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)				V	V	V	V																		V																								
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)				V	V	V												V																															
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)				V	V	V							V					V																															
FOCUS C-MAX	1.6L DIESEL	CDP(Compact Disc Player)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	CMR(Camera Module Rear)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	D_DCU(Driver Door Control Unit)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)				V	V	V	V																																										
FOCUS C-MAX	1.6L DIESEL	EPS(Electronic Power Steering)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	FACM(Fuel Additive Control Module)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	FFH(Fuel Fired Coolant Heating Module)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	GEM(Generic Electronic Module)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)				V	V	V							V					V																															
FOCUS C-MAX	1.6L DIESEL	IC(Instrument Cluster)				V	V	V	V																																										
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)				V	V	V												V																															
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)				V	V	V							V					V																															
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)				V	V	V																													V														
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)				V	V	V												V																															
FOCUS C-MAX	1.6L DIESEL	RETM(Rear Entertainment Module)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	RKE(Remote Keyless Entry)				V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)				V	V	V												V																															
FOCUS C-MAX	1.6L DIESEL	BCMii(Body Control Module)				V	V	V							V					V																															
FOCUS C-MAX	1.6L DIESEL	DDM(Driver's Door Module)				V	V	V							V					V																															
FOCUS C-MAX	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)				V	V	V							V					V																															
FOCUS C-MAX	1.6L DIESEL	HVAC(Heating Ventilation Air Condtioning)				V	V	V												V																															
FOCUS C-MAX	1.6L DIESEL	IPM-A(Image Processing Module A)				V	V								V					V																															
FOCUS C-MAX	1.6L DIESEL	IPM-B(Image Processing Module B)				V	V								V																																			
FOCUS C-MAX	1.6L DIESEL	IPC(Instrument Panel Control Module)				V	V	V	V						V					V																															
FOCUS C-MAX	1.6L DIESEL	PSCM(Power Steering Control Module)				V	V	V							V					V																															
FOCUS C-MAX	1.6L DIESEL	RFA(Remote Function Actuator)				V	V	V							V					V																															
FOCUS C-MAX	1.6L DIESEL	RGTM(Rear Gate/Trunk Module)				V	V	V												V																															
FOCUS C-MAX	1.6L DIESEL	SASM(Steering Angle Sensor Module)				V	V	V							V					V																															
FOCUS C-MAX	1.6L DIESEL	SRM(Speech Recognition Module)				V	V	V												V																															
FOCUS C-MAX	1.6L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)				V	V								V					V																															
FOCUS C-MAX	1.6L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)				V	V								V					V																															
FOCUS C-MAX	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FOCUS C-MAX	1.6L GASOLINE	SYSTEM SEARCH																																																		
FOCUS C-MAX	1.6L GASOLINE	PCM(PowerTrain Control Module)				V	V	V												V																																
FOCUS C-MAX	1.6L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V																																												
FOCUS C-MAX	1.6L GASOLINE	ACM(Audio Control Module)				V	V	V																																												
FOCUS C-MAX	1.6L GASOLINE	CDP(Compact Disc Player)				V	V	V																																												
FOCUS C-MAX	1.6L GASOLINE	CMR(Camera Module Rear)				V	V	V																																												
FOCUS C-MAX	1.6L GASOLINE	D_DCU(Driver Door Control Unit)				V	V	V																																												
FOCUS C-MAX	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)				V	V	V							V																																					
FOCUS C-MAX	1.6L GASOLINE	EPS(Electronic Power Steering)				V	V	V																																												
FOCUS C-MAX	1.6L GASOLINE	FFH(Fuel Fired Coolant Heating Module)				V	V	V							V																																					
FOCUS C-MAX	1.6L GASOLINE	GEM(Generic Electronic Module)				V	V	V																																												
FOCUS C-MAX	1.6L GASOLINE	HCM(Headlamp Control Module)				V	V	V							V																																					
FOCUS C-MAX	1.6L GASOLINE	IC(Instrument Cluster)				V	V	V	V																																											
FOCUS C-MAX	1.6L GASOLINE	PAM(Parking Aid Module)				V	V	V							V																																					
FOCUS C-MAX	1.6L GASOLINE	PDM(Passenger's Door Module)				V	V	V																																												
FOCUS C-MAX	1.6L GASOLINE	RCM(Restraint Control Module)				V	V	V																													V																
FOCUS C-MAX	1.6L GASOLINE	RETM(Rear Entertainment Module)				V	V	V																																												
FOCUS C-MAX	1.6L GASOLINE	RKE(Remote Keyless Entry)				V	V	V							V																																					
FOCUS C-MAX	1.6L GASOLINE	GDM(Generic Display Module)				V	V	V							V																																					
FOCUS C-MAX	1.6L GASOLINE	NAV(Navigation System)				V	V	V							V																																					
FOCUS C-MAX	1.6L GASOLINE	RL_DCU(Rear Left Door Control Unit)				V	V	V																																												
FOCUS C-MAX	1.6L GASOLINE	RR_DCU(Rear Right Door Control Unit)				V	V	V																																												
FOCUS C-MAX	1.6L GASOLINE	SRM(Speech Recognition Module)				V	V	V							V																																					
FOCUS C-MAX	1.6L GASOLINE	TCM(Transmission Control Module)				V	V	V																																												
FOCUS C-MAX	1.8L GASOLINE	SYSTEM SEARCH																																																		
FOCUS C-MAX	1.8L GASOLINE	PCM(PowerTrain Control Module)				V	V	V	V					V	V	V				V	V																															
FOCUS C-MAX	1.8L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V	V																		V																									
FOCUS C-MAX	1.8L GASOLINE	ACM(Audio Control Module)				V	V	V																																												
FOCUS C-MAX	1.8L GASOLINE	CMR(Camera Module Rear)				V	V	V																																												
FOCUS C-MAX	1.8L GASOLINE	CDP(Compact Disc Player)				V	V	V																																												
FOCUS C-MAX	1.8L GASOLINE	D_DCU(Driver Door Control Unit)				V	V	V	V																																											
FOCUS C-MAX	1.8L GASOLINE	EATC(Electronic Automatic Temperature Control)				V	V	V																																												
FOCUS C-MAX	1.8L GASOLINE	EPB(Electronic Parking Brake)				V	V	V																																												
FOCUS C-MAX	1.8L GASOLINE	EPS(Electronic Power Steering)				V	V	V																																												
FOCUS C-MAX	1.8L GASOLINE	FFH(Fuel Fired Coolant Heating Module)				V	V	V																																												
FOCUS C-MAX	1.8L GASOLINE	GDM(Generic Display Module)				V	V	V																																												
FOCUS C-MAX	1.8L GASOLINE	GEM(Generic Electronic Module)				V	V	V	V																																											
FOCUS C-MAX	1.8L GASOLINE	HCM(Headlamp Control Module)				V	V	V																																												
FOCUS C-MAX	1.8L GASOLINE	IC(Instrument Cluster)				V	V	V	V																																											
FOCUS C-MAX	1.8L GASOLINE	NAV(Navigation System)				V	V	V																																												
FOCUS C-MAX	1.8L GASOLINE	PAM(Parking Aid Module)				V	V	V																																												
FOCUS C-MAX	1.8L GASOLINE	PDM(Passenger's Door Module)				V	V	V	V																																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FOCUS C-MAX	1.8L GASOLINE	RCM(Restraint Control Module)				V	V	V																													V															
FOCUS C-MAX	1.8L GASOLINE	RETM(Rear Entertainment Module)				V	V	V																																													
FOCUS C-MAX	1.8L GASOLINE	RKE(Remote Keyless Entry)				V	V	V																																													
FOCUS C-MAX	1.8L GASOLINE	SRM(Speech Recognition Module)				V	V	V																																													
FOCUS C-MAX	2.0L DIESEL	SYSTEM SEARCH																																																			
FOCUS C-MAX	2.0L DIESEL	PCM(PowerTrain Control Module)				V	V	V												V																							V	V								
FOCUS C-MAX	2.0L DIESEL	ABS(Anti-Lock Brake System)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	ACM(Audio Control Module)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	BCMii(Body Control Module)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	DDM(Driver's Door Module)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	HCM(Headlamp Control Module)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	IPM-A(Image Processing Module A)				V	V													V																																	
FOCUS C-MAX	2.0L DIESEL	IPM-B(Image Processing Module B)				V	V																																														
FOCUS C-MAX	2.0L DIESEL	IPC(Instrument Panel Control Module)				V	V	V	V											V																																	
FOCUS C-MAX	2.0L DIESEL	PAM(Parking Aid Module)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	PDM(Passenger's Door Module)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	PSCM(Power Steering Control Module)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	RCM(Restraint Control Module)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	RFA(Remote Function Actuator)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	SASM(Steering Angle Sensor Module)				V	V	V												V																																	
FOCUS C-MAX	2.0L DIESEL	SRM(Speech Recognition Module)				V	V													V																																	
FOCUS C-MAX	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)				V	V													V																																	
FOCUS C-MAX	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)				V	V													V																																	
FOCUS C-MAX	2.0L GASOLINE	SYSTEM SEARCH																																																			
FOCUS C-MAX	2.0L GASOLINE	PCM(PowerTrain Control Module)				V	V	V	V					V	V	V				V	V																																
FOCUS C-MAX	2.0L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V	V																		V																											
FOCUS C-MAX	2.0L GASOLINE	ACM(Audio Control Module)				V	V	V																																													
FOCUS C-MAX	2.0L GASOLINE	CDP(Compact Disc Player)				V	V	V																																													
FOCUS C-MAX	2.0L GASOLINE	CMR(Camera Module Rear)				V	V	V																																													
FOCUS C-MAX	2.0L GASOLINE	D_DCU(Driver Door Control Unit)				V	V	V	V																																												
FOCUS C-MAX	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)				V	V	V																																													
FOCUS C-MAX	2.0L GASOLINE	EPB(Electronic Parking Brake)				V	V	V																																													
FOCUS C-MAX	2.0L GASOLINE	EPS(Electronic Power Steering)				V	V	V																																													
FOCUS C-MAX	2.0L GASOLINE	FFH(Fuel Fired Coolant Heating Module)				V	V	V																																													
FOCUS C-MAX	2.0L GASOLINE	GDM(Generic Display Module)				V	V	V																																													
FOCUS C-MAX	2.0L GASOLINE	GEM(Generic Electronic Module)				V	V	V	V																																												
FOCUS C-MAX	2.0L GASOLINE	HCM(Headlamp Control Module)				V	V	V																																													
FOCUS C-MAX	2.0L GASOLINE	IC(Instrument Cluster)				V	V	V	V																																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
FOCUS C-MAX	2.0L GASOLINE	NAV(Navigation System)				V	V	V																																												
FOCUS C-MAX	2.0L GASOLINE	PAM(Parking Aid Module)				V	V	V																																												
FOCUS C-MAX	2.0L GASOLINE	PDM(Passenger's Door Module)				V	V	V	V																																											
FOCUS C-MAX	2.0L GASOLINE	RCM(Restraint Control Module)				V	V	V																													V														
FOCUS C-MAX	2.0L GASOLINE	RETM(Rear Entertainment Module)				V	V	V																																												
FOCUS C-MAX	2.0L GASOLINE	RKE(Remote Keyless Entry)				V	V	V																																												
FOCUS C-MAX	2.0L GASOLINE	SRM(Speech Recognition Module)				V	V	V																																												
FUSION	1.4L DIESEL	SYSTEM SEARCH																																																		
FUSION	1.4L DIESEL	PCM(PowerTrain Control Module)				V	V	V	V					V	V	V				V																																
FUSION	1.4L DIESEL	TCM(Transmission Control Module)				V	V	V																																												
FUSION	1.4L DIESEL	ABS(Anti-Lock Brake System)				V	V	V	V																																											
FUSION	1.4L DIESEL	IC(Instrument Cluster)				V	V	V	V						V																																					
FUSION	1.4L DIESEL	ACM(Audio Control Module)				V	V	V																																												
FUSION	1.4L DIESEL	EATC(Electronic Automatic Temperature Control)				V	V	V																																												
FUSION	1.4L DIESEL	GEM(Generic Electronic Module)				V	V	V	V																																											
FUSION	1.4L DIESEL	SRM(Speech Recognition Module)				V	V	V												V																																
FUSION	1.4L DIESEL	RCM(Restraint Control Module)				V	V	V																																												
FUSION	1.4L DIESEL	PATS(Passive Anti Theft System)-BETA																																																		
FUSION	1.6L DIESEL	SYSTEM SEARCH																																																		
FUSION	1.6L DIESEL	PCM(PowerTrain Control Module)				V	V	V						V	V	V				V																																
FUSION	1.6L DIESEL	TCM(Transmission Control Module)				V	V	V																																												
FUSION	1.6L DIESEL	ABS(Anti-Lock Brake System)				V	V	V	V																																											
FUSION	1.6L DIESEL	IC(Instrument Cluster)				V	V	V	V						V																																					
FUSION	1.6L DIESEL	ACM(Audio Control Module)				V	V	V																																												
FUSION	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)				V	V	V																																												
FUSION	1.6L DIESEL	GEM(Generic Electronic Module)				V	V	V	V																																											
FUSION	1.6L DIESEL	SRM(Speech Recognition Module)				V	V	V												V																																
FUSION	1.6L DIESEL	RCM(Restraint Control Module)				V	V	V																																												
FUSION	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V												V							V																										
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)			V	V													V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V							V					V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)			V	V	V	V											V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V													V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)			V	V	V							V					V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)			V	V													V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V											V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)			V	V													V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)			V	V													V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)			V	V													V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)			V	V													V																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)			V	V													V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)			V	V	V							V	V				V																						V	V	V							
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V												V							V																										
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)			V	V													V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V							V					V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)			V	V	V	V											V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)			V	V													V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)			V	V	V							V					V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)			V	V													V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)			V	V	V	V											V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)			V	V													V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)			V	V	V												V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)			V	V													V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)			V	V													V																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)			V	V													V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)			V	V													V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)			V	V	V												V																						V	V								
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V												V							V																									
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)			V	V													V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V							V					V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)			V	V	V	V											V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)			V	V													V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)			V	V	V							V					V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)			V	V													V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)			V	V	V	V											V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)			V	V													V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)			V	V													V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)			V	V													V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)			V	V													V																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)			V	V													V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)			V	V	V												V																						V	V		V						
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V												V							V																									
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)			V	V													V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V							V					V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)			V	V	V	V											V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)			V	V	V							V																																				
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)			V	V								V																																				
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V								V					V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)			V	V	V							V					V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)			V	V													V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V											V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)			V	V	V																																												
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)			V	V													V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)			V	V													V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)			V	V													V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)			V	V													V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)			V	V	V												V																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)			V	V	V							V	V				V																						V										
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V												V							V																										
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V							V					V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)			V	V	V	V											V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)			V	V	V							V					V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)			V	V	V	V											V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)			V	V	V												V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)			V	V	V							V	V				V																							V									
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TCM(Transmission Control Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)			V	V	V												V							V																										
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)			V	V	V							V					V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)			V	V	V	V											V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CDP(Compact Disc Player)			V	V	V							V																																				
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CMR(Camera Module Rear)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DABM(Digital Audio Broadcast Module)			V	V								V																																				
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver's Seat Module)			V	V								V					V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)			V	V	V							V					V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)			V	V	V	V											V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	NAV(Navigation System)			V	V	V																																												
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PBM(Parking Brake Control Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RHVAC(Rear Heating Ventilation Air Conditioning)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module - Left)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module - Right)			V	V													V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)			V	V	V												V																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)			V	V													V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)			V	V	V	V					V	V	V				V	V	V	V	V	V	V																										
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V						V												V																										
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V	V						V					V											V	V	V	V																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V	V						V					V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V						V					V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V							V					V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V							V					V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V							V					V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V							V					V																		V														
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)			V	V	V	V						V					V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)			V	V	V																																											
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)			V	V	V	V						V					V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V							V					V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V						V																																					
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V	V	V						V																																					
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V							V					V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)			V	V	V	V						V																																					
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V							V					V																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)			V	V	V							V																																					
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)			V	V	V							V					V																																
F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																																																
F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)			V	V	V	V					V	V	V				V	V		V	V	V	V																										
F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)			V	V	V	V						V												V																										
F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																
F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)			V	V	V	V						V					V										V	V	V	V																			
F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)			V	V	V	V						V					V																																
F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V						V					V																																
F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)			V	V	V							V					V																																
F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)			V	V	V							V					V																																
F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)			V	V	V							V					V																																
F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)			V	V	V							V					V																		V														
F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)			V	V	V	V						V					V																																
F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)			V	V	V																																											
F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)			V	V	V	V						V					V																																
F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)			V	V	V							V					V																																
F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V						V																																					
F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)			V	V	V	V						V																																					
F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)			V	V	V							V					V																																
F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)			V	V	V	V						V																																					
F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)			V	V	V							V					V																																
F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)			V	V	V							V																																					
F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)			V	V	V							V					V																																
F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)		V	V	V						V	V	V				V	V	V	V	V	V	V																									
F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)		V	V	V	V						V												V													V												
F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)		V	V	V							V					V																																
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)		V	V	V							V					V																																
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)		V	V	V							V																																				
F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V						V																																				
F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)		V	V	V							V																																				
F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)		V	V	V							V					V																															
F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)		V	V	V							V					V																															
F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)		V	V	V	V						V																																				
F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V						V																	V	V																		
F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)		V	V	V							V					V																															
F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V						V					V																V																
F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)		V	V	V	V						V																										V											
F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)		V	V	V	V						V																																				
F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)		V	V	V							V					V																															
F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)		V	V	V	V											V																															
F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)		V	V	V	V						V																																				
F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)		V	V	V							V					V																	V														
F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)		V	V	V							V																																				
F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)		V	V	V	V						V					V																															
F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)		V	V	V	V						V	V				V			V	V	V	V												V													
F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)		V	V	V							V					V																															
F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)		V	V	V	V					V	V	V				V	V		V	V	V	V																									
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)		V	V	V	V												V		V	V	V	V																									
F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)		V	V	V	V						V																																				
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)		V	V	V					V																																						
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)		V	V	V	V						V												V													V												
F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)		V		V	V																																										
F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)		V	V	V	V				V																																						
F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)		V	V	V	V				V																																						
F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)		V		V	V																																										
F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)		V		V	V																																										
F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)		V	V	V	V						V																										V											
F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)		V		V	V																																										
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)		V		V	V																																										
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)		V		V																																											
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)		V	V	V	V																							V																				
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)		V		V	V																																										
F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)		V	V	V							V																																				
F150	4.6L(BETA)	3V	SYSTEM SEARCH																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V	V	V	V	V	V																									
F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)			V	V	V	V						V												V													V												
F150	4.6L(BETA)	3V	ACM(Audio Control Module)			V	V	V							V					V																																
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)			V	V	V							V																																				
F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V						V																																				
F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)			V	V	V							V																																				
F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)			V	V	V							V					V																															
F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)			V	V	V							V					V																															
F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)			V	V	V	V						V																																				
F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V						V																	V	V																		
F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)			V	V	V							V					V																															
F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V						V					V																V															
F150	4.6L(BETA)	3V	IC(Instrument Cluster)			V	V	V	V						V																										V										
F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)			V	V	V	V						V																																				
F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)			V	V	V							V					V																															
F150	4.6L(BETA)	3V	PAM(Parking Aid Module)			V	V	V	V											V																															
F150	4.6L(BETA)	3V	PRB(Power Running Board)			V	V	V	V						V																																				
F150	4.6L(BETA)	3V	RCM(Restraint Control Module)			V	V	V							V					V																	V														
F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)			V	V	V							V																																				
F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)			V	V	V	V						V					V																															
F150	4.6L(BETA)	3V	TCM(Transmission Control Module)			V	V	V	V						V	V				V			V	V	V	V												V													
F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)			V	V	V							V					V																															
F150	5.0L	TiVCT	SYSTEM SEARCH																																															
F150	5.0L	TiVCT	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V	V	V	V	V	V																									
F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)			V	V	V	V						V												V													V												
F150	5.0L	TiVCT	ACM(Audio Control Module)			V	V	V							V					V																																
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)			V	V	V							V																																				
F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V						V																																				
F150	5.0L	TiVCT	DSM(Driver's Seat Module)			V	V	V							V																																				
F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)			V	V	V							V					V																															
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V							V					V																															
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V							V																																				
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V	V						V					V																															
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V							V					V																															
F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V						V					V																															
F150	5.0L	TiVCT	FDIM(Front Display Interface Module)			V	V	V	V						V																																				
F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V						V																	V	V																		
F150	5.0L	TiVCT	GPSM(Global Positioning System Module)			V	V	V							V					V																															
F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V						V					V																															
F150	5.0L	TiVCT	IC(Instrument Cluster)			V	V	V	V						V					V																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)			V	V	V	V						V																																					
F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)			V	V	V							V					V																																
F150	5.0L	TiVCT	PAM(Parking Aid Module)			V	V	V	V											V																																
F150	5.0L	TiVCT	PAM(Parking Aid Module)			V	V	V							V					V																																
F150	5.0L	TiVCT	PRB(Power Running Board)			V	V	V	V						V																																					
F150	5.0L	TiVCT	PSCM(Power Steering Control Module)			V	V	V							V					V																																
F150	5.0L	TiVCT	RCM(Restraint Control Module)			V	V	V							V					V																	V															
F150	5.0L	TiVCT	RTM(Radio Transceiver Module)			V	V	V							V					V																																
F150	5.0L	TiVCT	SCCM(Steering Column Control Module)			V	V	V	V						V					V																																
F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)			V	V	V							V																																					
F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)			V	V	V	V						V					V																																
F150	5.0L	TiVCT	TCM(Transmission Control Module)			V	V	V	V						V	V				V			V	V	V	V												V														
F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)			V	V	V							V					V																																
F150	5.4L	3V	2009 ~	SYSTEM SEARCH																																																
F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)		V	V	V	V					V	V	V				V	V																															
F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)		V	V	V	V						V												V													V												
F150	5.4L	3V	2009 ~	ACM(Audio Control Module)		V	V	V							V					V																																
F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)		V	V	V							V					V																																
F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V						V																																					
F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)		V	V	V	V						V																																					
F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)		V	V	V							V					V																																
F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)		V	V	V							V					V																																
F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)		V	V	V	V						V																																					
F150	5.4L	3V	2009 ~	GEMS/JB(Generic Electronic Module/Smart Junction Box)		V	V	V	V						V																	V	V																			
F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)		V	V	V							V					V																																
F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V						V					V																V																
F150	5.4L	3V	2009 ~	IC(Instrument Cluster)		V	V	V	V						V																											V										
F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)		V	V	V	V						V																																					
F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)		V	V	V							V					V																																
F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)		V	V	V	V											V																																
F150	5.4L	3V	2009 ~	PRB(Power Running Board)		V	V	V							V																																					
F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)		V	V	V							V					V																	V															
F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)		V	V	V							V																																					
F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)		V	V	V	V						V					V																																
F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)		V	V	V	V						V	V				V			V	V	V	V												V														
F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)		V	V	V							V					V																																
F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																																																
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)		V	V	V	V					V	V	V				V	V		V	V	V	V																										
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)		V	V	V	V												V		V	V	V	V																										
F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)		V	V	V	V						V																																					
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)		V	V	V					V																																							
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)		V	V	V	V						V												V													V												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)		V		V	V																																											
F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)		V	V	V	V				V																																							
F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)		V	V	V	V				V																																							
F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)		V		V	V																																											
F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)		V		V	V																																											
F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)		V	V	V	V						V																											V										
F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)		V		V	V																																											
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)		V		V	V																																											
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)		V		V																																												
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)		V	V	V	V																							V																				
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)		V		V	V																																											
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)		V	V	V	V																																											
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)		V	V	V																																												
F150	6.2L(BETA)	2V	SYSTEM SEARCH																																																	
F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)			V	V	V	V											V	V																															
F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)			V	V	V	V						V												V																									
F150	6.2L(BETA)	2V	ACM(Audio Control Module)			V	V	V							V					V																																
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)			V	V	V							V																																					
F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)			V	V	V							V																																					
F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)			V	V	V							V					V																																
F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)			V	V	V							V					V																																
F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)			V	V	V																																												
F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V																							V	V																			
F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)			V	V	V							V					V																																
F150	6.2L(BETA)	2V	IC(Instrument Cluster)			V	V	V	V						V																											V										
F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)			V	V	V	V						V																																					
F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)			V	V	V							V					V																																
F150	6.2L(BETA)	2V	PAM(Parking Aid Module)			V	V	V	V						V					V																																
F150	6.2L(BETA)	2V	PRB(Power Running Board)			V	V	V							V																																					
F150	6.2L(BETA)	2V	RCM(Restraint Control Module)			V	V	V							V					V																	V															
F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)			V	V	V							V																																					
F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)			V	V	V	V											V																																
F150	6.2L(BETA)	2V	TCM(Transmission Control Module)			V	V	V	V						V	V				V			V	V	V	V												V													
F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)			V	V	V							V					V																																
F150	Other	2004 ~ 2008	SYSTEM SEARCH																																																	
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)			V	V	V	V					V	V	V				V	V		V	V	V	V																									
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)			V	V	V	V												V		V	V	V	V																									
F150	Other	2004 ~ 2008	4X4(4x4 Control Module)			V	V	V	V						V																																					
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)			V	V	V					V																																							
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)			V	V	V	V						V												V													V												
F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)			V	V	V	V				V																																							

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)			V	V	V	V				V																																							
F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)			V		V	V																																											
F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)			V		V	V																																											
F150	Other	2004 ~ 2008	IC(Instrument Cluster)			V	V	V	V						V																											V										
F150	Other	2004 ~ 2008	PAM(Parking Aid Module)			V		V	V																																											
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)			V		V	V																																											
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)			V		V																																												
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)			V	V	V	V																							V																				
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)			V		V	V																																											
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)			V	V	V	V																																											
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)			V	V	V																																												
F250	7.3L	SYSTEM SEARCH																																																		
F250	7.3L	PCM(PowerTrain Control Module)				V		V																																												
F250	7.3L	ABS(Anti-Lock Brake System)				V	V	V	V																																											
F250	7.3L	ECS(Electronic Crash Sensor)				V	V	V																																												
F250	7.3L	GEM(Generic Electronic Module)				V	V																																													
F250	6.2L	SYSTEM SEARCH																																																		
F250	6.2L	PCM(Powertrain Control Module)				V	V	V	V					V	V	V				V	V	V	V	V	V	V																										
F250	6.2L	ABS(Anti-Lock Brake System)				V	V	V	V						V					V							V													V													
F250	6.2L	ACM(Audio Control Module)				V	V	V							V					V									V																								
F250	6.2L	APIM(Accessory Protocol Interface Module)				V	V	V							V					V																																	
F250	6.2L	BCMii(Body Control Module)				V	V	V							V					V										V																							
F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)				V	V	V	V						V																																						
F250	6.2L	DSM(Driver Seat Module)				V	V	V	V						V																																						
F250	6.2L	GPSM(Global Positioning System Module)				V	V	V												V																																	
F250	6.2L	HVAC(Heating Ventilation Air Conditioning)				V	V	V	V						V					V																																	
F250	6.2L	IPC(Instrument Panel Control Module)				V	V	V	V						V					V																																	
F250	6.2L	PAM(Parking Aid Module)				V	V	V												V																																	
F250	6.2L	RCM(Restraint Control Module)				V	V	V												V																	V																
F250	6.2L	SCCM(Streering Colume Control Module)				V	V	V	V						V					V																																	
F250	6.2L	TBC(Trailer Brake Control Module)				V	V	V																																													
F250	6.2L	TCCM(Transfer Case Control Module)				V	V	V	V						V					V																																	
F250	6.2L	TPM(Tire Pressure Monitor)				V	V	V							V					V																																	
F250	6.0L Diesel	SYSTEM SEARCH																																																		
F250	6.0L Diesel	PCM(PowerTrain Control Module)				V	V	V						V	V	V				V	V																																
F250	6.0L Diesel	PCM(PowerTrain Control Module)				V	V	V												V																																	
F250	6.0L Diesel	PCM(PowerTrain Control Module)				V	V	V	V												V		V	V	V	V																											
F250	6.0L Diesel	ABS(Anti-Lock Brake System)				V		V	V																		V																										
F250	6.0L Diesel	GEM(Generic Electronic Module)				V		V																																												
F250	6.0L Diesel	HEC(Hybrid Electrical Cluster)				V	V	V	V																																											
F250	6.0L Diesel	OTC(Overhead Trip Computer)				V		V																																												
F250	6.0L Diesel	PAM(Parking Aid Module)				V		V																																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
F250	6.0L Diesel	PATS(Passive Anti Theft System)				V	V	V	V																																											
F250	6.0L Diesel	RCM(Restraint Control Module)				V	V	V																																												
F250	6.0L Diesel	TCM(Transmission Control Module)				V		V	V																																											
F250	6.0L Diesel	TCM(Transmission Control Module)				V	V	V							V	V																						V													
F250	6.0L Diesel	TCM(Transmission Control Module)				V		V												V																																
F250	6.0L Diesel	VSM(Vehicle Security Module)				V		V																																												
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)		V	V	V	V						V	V				V		V																														
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)		V	V	V							V	V				V	V		V	V	V	V																										
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)		V	V	V	V						V													V																									
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)		V	V	V	V						V					V								V													V												
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)		V	V	V							V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)		V	V	V							V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)		V	V	V							V																																					
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)		V	V	V							V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)		V	V	V	V						V					V										V		V																					
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)		V	V	V							V																																					
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V						V																																					
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)		V	V	V	V						V																																					
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)		V	V	V	V						V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)		V	V	V							V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)		V	V	V							V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)		V	V	V	V						V																																					
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V						V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)		V	V	V	V						V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)		V	V	V							V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)		V	V	V							V					V																	V															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)		V	V	V							V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)		V	V	V	V						V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)		V	V	V							V																																					
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)		V	V	V	V						V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)		V	V	V	V						V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)		V	V	V	V						V	V				V		V																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)		V	V	V																				V																									
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)		V	V	V	V						V					V								V													V												
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)		V	V	V							V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)		V	V	V							V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)		V	V	V	V																																											
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)		V	V	V							V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)		V	V	V							V					V										V																							
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)		V	V	V							V																																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V						V																																					
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)		V	V	V	V						V																																					
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)		V	V	V							V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V						V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)		V	V	V	V						V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)		V	V	V							V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)		V	V	V												V																	V															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)		V	V	V	V						V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V						V																																					
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)		V	V	V							V																																					
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)		V	V	V	V						V					V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)		V	V	V							V	V				V	V		V	V	V	V																										
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)		V	V	V							V					V																																	
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V	V						V	V				V	V																																
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)			V	V	V	V						V																																						
KA	KA	SYSTEM SEARCH																																																		
KA	KA	PCM(PowerTrain Control Module)				V	V	V	V																																												
KA	KA	ABS(Anti-Lock Brake System)				V	V	V					V																																								
KA	KA	RCM(Restraint Control Module)				V	V	V	V				V																																								
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V					V	V	V				V	V	V	V	V	V	V																										
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V						V					V								V																									
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V							V					V																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V	V						V					V																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V						V					V																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V	V						V					V																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V							V					V																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V							V					V																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V							V					V																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V							V					V																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V							V					V																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V							V					V																	V															
KUGA	2.0L DIESEL	SYSTEM SEARCH																																																		
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)				V	V	V												V																																	
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)				V	V	V	V											V																							V	V									
KUGA	2.0L DIESEL	TCM(Transmission Control Module)				V	V	V												V																																	
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)				V	V	V	V																		V																											
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)				V	V	V												V																																	
KUGA	2.0L DIESEL	ACM(Audio Control Module)				V	V	V																																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
KUGA	2.0L DIESEL	ACM(Audio Control Module)				V	V	V							V					V																																
KUGA	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)				V	V	V												V																																
KUGA	2.0L DIESEL	APIM(Accessory Protocol Interface Module)				V	V	V												V																																
KUGA	2.0L DIESEL	AWD(All Wheel Drive Module)				V	V	V							V																																				
KUGA	2.0L DIESEL	BCMii(Body Control Module)				V	V	V							V					V																																
KUGA	2.0L DIESEL	CCMii(Cruise Control Module)				V	V	V							V					V																																
KUGA	2.0L DIESEL	CMR(Camera Module Rear)				V	V	V																																												
KUGA	2.0L DIESEL	D_DCU(Driver Door Control Unit)				V	V	V	V																																											
KUGA	2.0L DIESEL	DDM(Driver's Door Module)				V	V	V												V																																
KUGA	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)				V	V	V																																												
KUGA	2.0L DIESEL	EPS(Electronic Power Steering)				V	V	V																																												
KUGA	2.0L DIESEL	FDSM(Front Distance Sensing Module)				V	V	V												V																																
KUGA	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)				V	V	V	V						V					V																																
KUGA	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)				V	V	V	V																																											
KUGA	2.0L DIESEL	GEM(Generic Electronic Module)				V	V	V	V																																											
KUGA	2.0L DIESEL	GPSM(Global Positioning System Module)				V	V	V												V																																
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)				V	V	V																																												
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)				V	V	V							V					V																																
KUGA	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)				V	V	V							V					V																																
KUGA	2.0L DIESEL	IPM-A(Image Processing Module A)				V	V								V					V																																
KUGA	2.0L DIESEL	IPM-B(Image Processing Module B)				V	V																																												
KUGA	2.0L DIESEL	IPC(Instrument Panel Control Module)				V	V	V	V						V					V																																
KUGA	2.0L DIESEL	IC(Instrument Cluster)				V	V	V	V																																											
KUGA	2.0L DIESEL	PAM(Parking Aid Module)				V	V	V																																												
KUGA	2.0L DIESEL	PAM(Parking Aid Module)				V	V	V							V					V																																
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)				V	V	V	V						V																																					
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)				V	V	V												V																																
KUGA	2.0L DIESEL	PSCM(Power Steering Control Module)				V	V	V												V																																
KUGA	2.0L DIESEL	RCM(Restraint Control Module)				V	V	V																																												
KUGA	2.0L DIESEL	RCM(Restraint Control Module)				V	V	V												V																	V															
KUGA	2.0L DIESEL	RFA(Remote Function Actuator)				V	V	V							V					V																																
KUGA	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)				V	V	V												V																																
KUGA	2.0L DIESEL	RETM(Rear Entertainment Module)				V	V	V																																												
KUGA	2.0L DIESEL	SASM(Steering Angle Sensor Module)				V	V	V												V																																
KUGA	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)				V	V	V	V											V																																
KUGA	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)				V	V	V	V											V																																
KUGA	2.0L DIESEL	SRM(Speech Recognition Module)				V	V	V																																												
KUGA	2.0L DIESEL	TRM(Trailer Module)				V	V	V	V											V																																
KUGA	2.5L GASOLINE	SYSTEM SEARCH																																																		
KUGA	2.5L GASOLINE	PCM(PowerTrain Control Module)				V	V	V						V	V	V				V																																
KUGA	2.5L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V																																												
KUGA	2.5L GASOLINE	ACM(Audio Control Module)				V	V	V																																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
KUGA	2.5L GASOLINE	AWD(All Wheel Drive Module)				V	V	V																																												
KUGA	2.5L GASOLINE	CMR(Camera Module Rear)				V	V	V																																												
KUGA	2.5L GASOLINE	D_DCU(Driver Door Control Unit)				V	V	V	V																																											
KUGA	2.5L GASOLINE	EATC(Electronic Automatic Temperature Control)				V	V	V																																												
KUGA	2.5L GASOLINE	EPS(Electronic Power Steering)				V	V	V																																												
KUGA	2.5L GASOLINE	FFH(Fuel Fired Coolant Heating Module)				V	V	V	V																																											
KUGA	2.5L GASOLINE	GEM(Generic Electronic Module)				V	V	V	V																																											
KUGA	2.5L GASOLINE	HCM(Headlamp Control Module)				V	V	V												V																																
KUGA	2.5L GASOLINE	IC(Instrument Cluster)				V	V	V	V																																											
KUGA	2.5L GASOLINE	PAM(Parking Aid Module)				V	V	V																																												
KUGA	2.5L GASOLINE	PDM(Passenger's Door Module)				V	V	V	V						V																																					
KUGA	2.5L GASOLINE	RCM(Restraint Control Module)				V	V	V																																												
KUGA	2.5L GASOLINE	RETM(Rear Entertainment Module)				V	V	V																																												
KUGA	2.5L GASOLINE	RKE(Remote Keyless Entry)				V	V	V																																												
KUGA	2.5L GASOLINE	SRM(Speech Recognition Module)				V	V	V																																												
KUGA	2.5L GASOLINE	TCM(Transmission Control Module)				V	V	V																																												
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)		V	V	V												V							V																									
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)		V	V													V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)		V	V	V							V					V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)		V	V	V	V											V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)		V	V													V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)		V	V	V							V					V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)		V	V													V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)		V	V	V	V											V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)		V	V													V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)		V	V	V												V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)		V	V													V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)		V	V													V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SDD-R(Side Obstacle Detection Control Module - Right)		V	V													V																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)		V	V													V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)		V	V	V							V	V				V																							V			V					
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)		V	V	V	V						V					V							V																									
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body Control Module)		V	V	V							V					V										V	V	V																				
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	CCMii(Cruise Control Module)		V	V	V												V														V																			
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DCDC(DC to DC Convertal Control Module)		V	V	V																																												
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DDM(Driver's Door Module)		V	V	V							V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSM(Driver Seat Module)		V	V	V	V						V																																					
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSP(Digital Signal Processing Module)		V	V	V							V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCIM(Front Controls Interface Module)		V	V	V	V						V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FDSM(Front Distance Sensing Module)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCDIM(Front Control/Display Interface Module)		V	V	V	V						V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GPSM(Global Positioning System Module)		V	V	V							V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GWM(Gateway Module A)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HCM(Headlamp Control Module)		V	V	V							V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HSWM(Heated Steering Wheel Module)		V	V	V	V						V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HUD(Head Up Display)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)		V	V	V							V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPC(Instrument Panel Control Module)		V	V	V	V						V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PAM(Parking Aid Module)		V	V	V							V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PDM(Passenger's Door Module)		V	V	V							V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PSCM(Power Steering Control Module)		V	V	V							V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RACM(Rear Audio Control Module)		V	V	V							V																																				
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RCM(Restraint Control Module)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RGTM(Rear Gate/Trunk Module)		V	V								V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RTM(Radio Transceiver Module)		V	V	V							V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCCM(Streering Colume Control Module)		V	V	V							V					V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-E(Seat Control Module E)		V	V	V	V																																										
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-G(Seat Control Module G)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-H(Seat Control Module H)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SDD-L(Side Obstacle Detection Control Module Left)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SDD-R(Side Obstacle Detection Control Module Right)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TRM(Trailer Module)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)		V	V	V												V																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)		V	V	V							V	V				V																							V			V					
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)		V	V	V	V						V					V							V																								
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)		V	V	V												V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)		V	V	V												V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)		V	V	V												V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)		V	V	V							V					V										V	V	V																		
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)		V	V	V												V														V																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DCDC(DC to DC Convertal Control Module)		V	V	V																																										
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)		V	V	V							V					V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver Seat Module)		V	V	V	V						V																																			
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSP(Digital Signal Processing Module)		V	V	V							V					V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)		V	V	V	V						V					V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)		V	V	V												V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)		V	V	V	V						V					V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)		V	V	V							V					V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GWM(Gateway Module A)		V	V	V												V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)		V	V	V	V											V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HSWM(Heated Steering Wheel Module)		V	V	V	V						V					V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HUD(Head Up Display)		V	V	V												V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)		V	V	V												V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)		V	V	V	V						V					V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)		V	V	V							V					V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)		V	V	V							V					V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)		V	V	V							V					V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RACM(Rear Audio Control Module)		V	V	V							V																																			
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)		V	V	V												V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)		V	V													V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RTM(Radio Transceiver Module)		V	V	V							V					V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCCM(Streering Colume Control Module)		V	V	V							V					V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-E(Seat Control Module E)		V	V	V																																									
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-G(Seat Control Module G)		V	V	V												V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-H(Seat Control Module H)		V	V	V												V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V											V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V											V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)		V	V	V												V																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)		V	V	V												V																														
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)		V	V	V							V	V				V																						V	V	V						
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)		V	V	V												V																														
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)		V	V	V												V							V																								
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)		V	V													V																														
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)		V	V	V							V					V																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)		V	V	V	V											V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)		V	V	V												V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)		V	V													V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)		V	V	V							V					V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)		V	V	V												V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)		V	V													V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)		V	V	V	V											V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)		V	V	V												V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)		V	V													V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)		V	V	V												V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)		V	V													V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)		V	V													V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)		V	V													V																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)		V	V													V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)		V	V	V												V							V																									
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)		V	V													V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)		V	V	V							V					V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)		V	V	V	V											V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)		V	V	V												V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)		V	V													V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)		V	V	V							V					V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)		V	V	V												V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)		V	V													V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)		V	V	V	V											V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)		V	V	V												V																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)		V	V	V												V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)		V	V	V											V																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)		V	V												V																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)		V	V	V											V																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)		V	V	V											V																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)		V	V												V																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)		V	V												V																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)		V	V												V																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)		V	V												V																																	
MONDEO	2012 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2012 MY	2.0L DIESEL	PCM(PowerTrain Control Module)			V	V	V											V																								V	V								
MONDEO	2012 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)			V	V	V											V							V																										
MONDEO	2012 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	BCMii(Body Control Module)			V	V	V	V										V																																	
MONDEO	2012 MY	2.0L DIESEL	CCMii(Cruise Control Module)			V	V	V	V										V																																	
MONDEO	2012 MY	2.0L DIESEL	CMR(Camera Module Rear)			V	V	V																																											
MONDEO	2012 MY	2.0L DIESEL	DDM(Driver's Door Module)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	DSM(Driver's Seat Module)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	HCM(Headlamp Control Module)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	IPM-A(Image Processing Module A)			V	V												V																																	
MONDEO	2012 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	PAM(Parking Aid Module)			V	V												V																																	
MONDEO	2012 MY	2.0L DIESEL	PBM(Parking Brake Control Module)			V	V												V																																	
MONDEO	2012 MY	2.0L DIESEL	PDM(Passenger's Door Module)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	PSCM(Power Steering Control Module)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	RCM(Restraint Control Module)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	RFA(Remote Function Actuator)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)			V	V												V																																	
MONDEO	2012 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)			V	V												V																																	
MONDEO	2012 MY	2.0L DIESEL	SRM(Speech Recognition Module)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	TCM(Transmission Control Module)			V	V	V											V																																	
MONDEO	2012 MY	2.0L DIESEL	TRM(Trailer Module)			V	V												V																																	
MONDEO	2012 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)			V	V												V																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)		V	V	V							V	V			V																								V	V	V							
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)		V	V	V											V																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)		V	V	V											V							V																										
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)		V	V												V																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)		V	V	V							V				V																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)		V	V	V	V											V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)		V	V	V												V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)		V	V													V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)		V	V	V							V					V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)		V	V	V												V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)		V	V													V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)		V	V	V	V											V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)		V	V	V												V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)		V	V													V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)		V	V	V												V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)		V	V													V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)		V	V													V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)		V	V													V																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)		V	V													V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)		V	V	V												V							V																									
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)		V	V													V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)		V	V	V							V					V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)		V	V	V	V											V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)		V	V	V												V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)		V	V													V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)		V	V	V							V					V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)		V	V	V												V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)		V	V													V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)		V	V	V	V											V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)		V	V	V												V																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)		V	V	V												V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)		V	V	V											V																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)		V	V												V																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)		V	V	V											V																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)		V	V	V											V																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)		V	V												V																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)		V	V												V																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)		V	V												V																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)		V	V												V																																	
MONDEO	2011 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2011 MY	2.0L DIESEL	PCM(PowerTrain Control Module)			V	V	V											V																							V	V								
MONDEO	2011 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)			V	V	V											V							V																										
MONDEO	2011 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	BCMii(Body Control Module)			V	V	V	V										V																																	
MONDEO	2011 MY	2.0L DIESEL	CCMii(Cruise Control Module)			V	V	V	V										V																																	
MONDEO	2011 MY	2.0L DIESEL	CMR(Camera Module Rear)			V	V	V																																												
MONDEO	2011 MY	2.0L DIESEL	DDM(Driver's Door Module)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	DSM(Driver's Seat Module)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	HCM(Headlamp Control Module)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	IPM-A(Image Processing Module A)			V	V												V																																	
MONDEO	2011 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	PAM(Parking Aid Module)			V	V												V																																	
MONDEO	2011 MY	2.0L DIESEL	PBM(Parking Brake Control Module)			V	V												V																																	
MONDEO	2011 MY	2.0L DIESEL	PDM(Passenger's Door Module)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	PSCM(Power Steering Control Module)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	RCM(Restraint Control Module)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	RFA(Remote Function Actuator)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)			V	V												V																																	
MONDEO	2011 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)			V	V												V																																	
MONDEO	2011 MY	2.0L DIESEL	SRM(Speech Recognition Module)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	TCM(Transmission Control Module)			V	V	V											V																																	
MONDEO	2011 MY	2.0L DIESEL	TRM(Trailer Module)			V	V												V																																	
MONDEO	2011 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)			V	V												V																																	
MONDEO	2011 MY	2.3L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2011 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)			V	V	V	V						V	V			V	V																																	
MONDEO	2011 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)			V	V	V											V																																	
MONDEO	2011 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)			V	V	V											V																																	
MONDEO	2011 MY	2.3L GASOLINE	BCMii(Body Control Module)			V	V	V	V										V																																	
MONDEO	2011 MY	2.3L GASOLINE	CCMii(Cruise Control Module)			V	V	V											V																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2011 MY	2.3L GASOLINE	CMR(Camera Module Rear)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	DDM(Driver's Door Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	DSM(Driver Seat Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	PAM(Parking Aid Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	PDM(Passenger's Door Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	RCM(Restraint Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	RFA(Remote Function Actuator)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	SRM(Speech Recognition Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	TCM(Transmission Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	TRM(Trailer Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)			V	V	V												V																																
MONDEO	2011 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2011 MY	2.5L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2011 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	BCMii(Body Control Module)			V	V	V	V											V																																
MONDEO	2011 MY	2.5L GASOLINE	CCMii(Cruise Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	CMR(Camera Module Rear)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	DDM(Driver's Door Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	DSM(Driver's Seat Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	HCM(Headlamp Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	PAM(Parking Aid Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	PDM(Passenger's Door Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	RCM(Restraint Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	RFA(Remote Function Actuator)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	SRM(Speech Recognition Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	TCM(Transmission Control Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	TRM(Trailer Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)			V	V	V												V																																
MONDEO	2011 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2010 MY	2.0L	DIESEL	SYSTEM SEARCH																																																
MONDEO	2010 MY	2.0L	DIESEL	PCM(PowerTrain Control Module)		V	V	V												V	V																						V									
MONDEO	2010 MY	2.0L	DIESEL	ABS(Anti-Lock Brake System)		V	V	V												V							V																										
MONDEO	2010 MY	2.0L	DIESEL	AHCM(Auxiliary Heater Control Module)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	DIESEL	BCMii(Body Control Module)		V	V	V							V					V																																	
MONDEO	2010 MY	2.0L	DIESEL	CCMii(Cruise Control Module)		V	V	V	V						V					V																																	
MONDEO	2010 MY	2.0L	DIESEL	CMR(Camera Module Rear)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	DIESEL	DDM(Driver's Door Module)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	DIESEL	DSM(Driver's Seat Module)		V	V	V							V					V																																	
MONDEO	2010 MY	2.0L	DIESEL	HCM(Headlamp Control Module)		V	V	V							V					V																																	
MONDEO	2010 MY	2.0L	DIESEL	HVAC(Heating Ventilation Air Conditioning)		V	V	V							V					V																																	
MONDEO	2010 MY	2.0L	DIESEL	IPC(Instrument Panel Control Module)		V	V	V							V					V																																	
MONDEO	2010 MY	2.0L	DIESEL	PAM(Parking Aid Module)		V	V	V							V					V																																	
MONDEO	2010 MY	2.0L	DIESEL	PBM(Parking Brake Control Module)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	DIESEL	PDM(Passenger's Door Module)		V	V	V							V					V																																	
MONDEO	2010 MY	2.0L	DIESEL	PSCM(Power Steering Control Module)		V	V	V							V					V																																	
MONDEO	2010 MY	2.0L	DIESEL	RCM(Restraint Control Module)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	DIESEL	RFA(Remote Function Actuator)		V	V	V							V					V																																	
MONDEO	2010 MY	2.0L	DIESEL	SASM(Steering Angle Sensor Module)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	DIESEL	SRM(Speech Recognition Module)		V	V								V					V																																	
MONDEO	2010 MY	2.0L	DIESEL	TCM(Transmission Control Module)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	DIESEL	TRM(Trailer Module)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	DIESEL	VDM(Vehicle Dynamic Module)		V	V	V							V					V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)		V	V	V												V																							V	V		V						
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)		V	V	V												V							V																										
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)		V	V													V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)		V	V	V							V					V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)		V	V	V	V											V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)		V	V	V							V																																					
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)		V	V								V																																					
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)		V	V								V					V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)		V	V	V							V					V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)		V	V	V												V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)		V	V													V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)		V	V	V	V											V																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)		V	V	V																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)		V	V	V												V																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)		V	V	V												V																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)		V	V	V												V																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)		V	V	V												V																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)		V	V	V												V																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)		V	V	V												V																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)		V	V													V																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)		V	V	V												V																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)		V	V	V												V																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)		V	V													V																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)		V	V													V																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)		V	V													V																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)		V	V	V												V																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)		V	V													V																																
MONDEO	2010 MY	2.3L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2010 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)			V	V	V	V					V	V				V	V																																
MONDEO	2010 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	BCMii(Body Control Module)			V	V	V	V										V																																
MONDEO	2010 MY	2.3L GASOLINE	CCMii(Cruise Control Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	CMR(Camera Module Rear)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	DDM(Driver's Door Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	DSM(Driver Seat Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	PAM(Parking Aid Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	PDM(Passenger's Door Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	RCM(Restraint Control Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	RFA(Remote Function Actuator)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	SRM(Speech Recognition Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	TCM(Transmission Control Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	TRM(Trailer Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)			V	V	V											V																																
MONDEO	2010 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2010 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2010 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)			V	V	V											V																																
MONDEO	2010 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)			V	V	V											V																																
MONDEO	2010 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)			V	V	V											V																																
MONDEO	2010 MY	2.5L GASOLINE	BCMii(Body Control Module)			V	V	V	V										V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2010 MY	2.5L GASOLINE	CCMii(Cruise Control Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	CMR(Camera Module Rear)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	DDM(Driver's Door Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	DSM(Driver's Seat Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	HCM(Headlamp Control Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	PAM(Parking Aid Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	PDM(Passenger's Door Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	RCM(Restraint Control Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	RFA(Remote Function Actuator)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	SRM(Speech Recognition Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	TCM(Transmission Control Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	TRM(Trailer Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)			V	V	V												V																																
MONDEO	2010 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)		V	V	V	V											V																								V								
MONDEO	2009 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)		V	V	V												V							V																										
MONDEO	2009 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)		V	V	V												V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)		V	V	V												V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)		V	V	V							V					V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)		V	V	V	V						V					V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)		V	V	V												V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)		V	V	V												V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)		V	V	V							V					V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)		V	V	V							V					V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)		V	V	V							V					V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)		V	V	V							V					V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)		V	V	V							V					V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)		V	V	V												V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)		V	V	V							V					V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)		V	V	V							V					V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)		V	V	V												V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)		V	V	V							V					V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)		V	V	V												V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)		V	V								V					V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	TRM(Trailer Module)		V	V	V												V																																
MONDEO	2009 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)		V	V	V							V					V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2009 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	2009 MY	1.8L DIESEL	PCM(PowerTrain Control Module)			V	V	V												V	V																						V								
MONDEO	2009 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)			V	V	V												V							V																								
MONDEO	2009 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	BCMii(Body Control Module)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	CCMii(Cruise Control Module)			V	V	V	V											V																															
MONDEO	2009 MY	1.8L DIESEL	CMR(Camera Module Rear)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	DDM(Driver's Door Module)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	DSM(Driver's Seat Module)			V	V													V																															
MONDEO	2009 MY	1.8L DIESEL	HCM(Headlamp Control Module)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)			V	V	V	V											V																															
MONDEO	2009 MY	1.8L DIESEL	PAM(Parking Aid Module)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	PBM(Parking Brake Control Module)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	PDM(Passenger's Door Module)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	PSCM(Power Steering Control Module)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	RCM(Restraint Control Module)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	RFA(Remote Function Actuator)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	SRM(Speech Recognition Module)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	TRM(Trailer Module)			V	V	V												V																															
MONDEO	2009 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)			V	V	V												V																															
MONDEO	2009 MY	2.0L DIESEL	SYSTEM SEARCH																																																
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)			V	V	V												V	V																						V								
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)			V	V	V												V																															
MONDEO	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)			V	V	V												V																															
MONDEO	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)			V	V	V												V							V																								
MONDEO	2009 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)			V	V	V												V																															
MONDEO	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)			V	V	V												V																															
MONDEO	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)			V	V	V												V																															
MONDEO	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)			V	V	V							V					V																															
MONDEO	2009 MY	2.0L DIESEL	BCMii(Body Control Module)			V	V	V							V					V																															
MONDEO	2009 MY	2.0L DIESEL	CCMii(Cruise Control Module)			V	V	V	V						V					V																															
MONDEO	2009 MY	2.0L DIESEL	CMR(Camera Module Rear)			V	V	V												V																															
MONDEO	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)			V	V	V												V																															
MONDEO	2009 MY	2.0L DIESEL	DSM(Driver's Seat Module)			V	V	V							V					V																															
MONDEO	2009 MY	2.0L DIESEL	HCM(Headlamp Control Module)			V	V	V							V					V																															
MONDEO	2009 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)			V	V	V							V					V																															
MONDEO	2009 MY	2.0L DIESEL	PAM(Parking Aid Module)			V	V	V							V					V																															
MONDEO	2009 MY	2.0L DIESEL	PBM(Parking Brake Control Module)			V	V	V												V																															
MONDEO	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)			V	V	V							V					V																															
MONDEO	2009 MY	2.0L DIESEL	PSCM(Power Steering Control Module)			V	V	V							V					V																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2009 MY	2.0L DIESEL	RFA(Remote Function Actuator)			V	V	V							V					V																																
MONDEO	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)			V	V								V					V																																
MONDEO	2009 MY	2.0L DIESEL	TRM(Trailer Module)			V	V	V												V																																
MONDEO	2009 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)			V	V	V							V					V																																
MONDEO	2009 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2009 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)			V	V	V	V						V	V				V	V																															
MONDEO	2009 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	BCMii(Body Control Module)			V	V	V	V											V																																
MONDEO	2009 MY	2.3L GASOLINE	CCMii(Cruise Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	CMR(Camera Module Rear)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	DDM(Driver's Door Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	DSM(Driver Seat Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	PAM(Parking Aid Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	PDM(Passenger's Door Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	RCM(Restraint Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	RFA(Remote Function Actuator)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	SRM(Speech Recognition Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	TCM(Transmission Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	TRM(Trailer Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)			V	V	V												V																																
MONDEO	2009 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2009 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2009 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	BCMii(Body Control Module)			V	V	V	V											V																																
MONDEO	2009 MY	2.5L GASOLINE	CCMii(Cruise Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	CMR(Camera Module Rear)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	DDM(Driver's Door Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	DSM(Driver's Seat Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	HCM(Headlamp Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	PAM(Parking Aid Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)			V	V	V												V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2009 MY	2.5L GASOLINE	PDM(Passenger's Door Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	RCM(Restraint Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	RFA(Remote Function Actuator)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	SRM(Speech Recognition Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	TCM(Transmission Control Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	TRM(Trailer Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)			V	V	V												V																																
MONDEO	2009 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)		V	V	V	V											V																								V								
MONDEO	2008 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)		V	V	V												V							V																										
MONDEO	2008 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)		V	V	V												V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)		V	V	V												V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)		V	V	V							V					V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)		V	V	V	V						V					V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)		V	V	V												V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)		V	V	V												V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)		V	V	V							V					V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)		V	V	V							V					V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)		V	V	V							V					V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)		V	V	V							V					V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)		V	V	V							V					V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)		V	V	V												V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)		V	V	V							V					V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)		V	V	V							V					V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)		V	V	V												V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)		V	V	V							V					V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)		V	V	V												V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)		V	V								V					V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	TRM(Trailer Module)		V	V	V												V																																
MONDEO	2008 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)		V	V	V							V					V																																
MONDEO	2008 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	2008 MY	1.8L DIESEL	PCM(PowerTrain Control Module)			V	V	V												V	V																						V								
MONDEO	2008 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)			V	V	V												V							V																										
MONDEO	2008 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	BCMii(Body Control Module)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	CCMii(Cruise Control Module)			V	V	V	V											V																																
MONDEO	2008 MY	1.8L DIESEL	CMR(Camera Module Rear)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	DDM(Driver's Door Module)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	DSM(Driver's Seat Module)			V	V													V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2008 MY	1.8L DIESEL	HCM(Headlamp Control Module)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)			V	V	V	V											V																																
MONDEO	2008 MY	1.8L DIESEL	PAM(Parking Aid Module)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	PBM(Parking Brake Control Module)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	PDM(Passenger's Door Module)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	PSCM(Power Steering Control Module)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	RCM(Restraint Control Module)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	RFA(Remote Function Actuator)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	SRM(Speech Recognition Module)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	TRM(Trailer Module)			V	V	V												V																																
MONDEO	2008 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2008 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)			V	V	V	V						V	V				V	V																																
MONDEO	2008 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	BCMii(Body Control Module)			V	V	V	V											V																																
MONDEO	2008 MY	2.3L GASOLINE	CCMii(Cruise Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	CMR(Camera Module Rear)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	DDM(Driver's Door Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	DSM(Driver Seat Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	PAM(Parking Aid Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	PDM(Passenger's Door Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	RCM(Restraint Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	RFA(Remote Function Actuator)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	SRM(Speech Recognition Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	TCM(Transmission Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	TRM(Trailer Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)			V	V	V												V																																
MONDEO	2008 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2008 MY	2.5L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2008 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	BCMii(Body Control Module)			V	V	V	V											V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2008 MY	2.5L GASOLINE	CCMii(Cruise Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	CMR(Camera Module Rear)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	DDM(Driver's Door Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	DSM(Driver's Seat Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	HCM(Headlamp Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	PAM(Parking Aid Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	PDM(Passenger's Door Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	RCM(Restraint Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	RFA(Remote Function Actuator)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	SRM(Speech Recognition Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	TCM(Transmission Control Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	TRM(Trailer Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)			V	V	V												V																																
MONDEO	2008 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)		V	V	V	V											V																								V								
MONDEO	2007 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)		V	V	V												V							V																										
MONDEO	2007 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)		V	V	V												V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)		V	V	V												V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)		V	V	V							V					V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)		V	V	V	V						V					V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)		V	V	V												V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)		V	V	V												V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)		V	V	V							V					V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)		V	V	V							V					V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)		V	V	V							V					V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)		V	V	V							V					V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)		V	V	V							V					V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)		V	V	V												V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)		V	V	V							V					V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)		V	V	V							V					V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)		V	V	V												V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)		V	V	V							V					V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)		V	V	V												V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)		V	V								V					V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	TRM(Trailer Module)		V	V	V												V																																
MONDEO	2007 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)		V	V	V							V					V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2007 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	2007 MY	1.8L DIESEL	PCM(PowerTrain Control Module)			V	V	V												V	V																						V								
MONDEO	2007 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)			V	V	V												V							V																								
MONDEO	2007 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	BCMii(Body Control Module)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	CCMii(Cruise Control Module)			V	V	V	V											V																															
MONDEO	2007 MY	1.8L DIESEL	CMR(Camera Module Rear)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	DDM(Driver's Door Module)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	DSM(Driver's Seat Module)			V	V													V																															
MONDEO	2007 MY	1.8L DIESEL	HCM(Headlamp Control Module)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)			V	V	V	V											V																															
MONDEO	2007 MY	1.8L DIESEL	PAM(Parking Aid Module)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	PBM(Parking Brake Control Module)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	PDM(Passenger's Door Module)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	PSCM(Power Steering Control Module)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	RCM(Restraint Control Module)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	RFA(Remote Function Actuator)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	SRM(Speech Recognition Module)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	TRM(Trailer Module)			V	V	V												V																															
MONDEO	2007 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2007 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)			V	V	V	V						V	V				V	V																															
MONDEO	2007 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	BCMii(Body Control Module)			V	V	V	V											V																															
MONDEO	2007 MY	2.3L GASOLINE	CCMii(Cruise Control Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	CMR(Camera Module Rear)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	DDM(Driver's Door Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	DSM(Driver Seat Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	PAM(Parking Aid Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	PDM(Passenger's Door Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	RCM(Restraint Control Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	RFA(Remote Function Actuator)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)			V	V	V												V																															
MONDEO	2007 MY	2.3L GASOLINE	SRM(Speech Recognition Module)			V	V	V												V																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2007 MY	2.3L GASOLINE	TCM(Transmission Control Module)			V	V	V												V																																
MONDEO	2007 MY	2.3L GASOLINE	TRM(Trailer Module)			V	V	V												V																																
MONDEO	2007 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)			V	V	V												V																																
MONDEO	2007 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2007 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2007 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	BCMii(Body Control Module)			V	V	V	V											V																																
MONDEO	2007 MY	2.5L GASOLINE	CCMii(Cruise Control Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	CMR(Camera Module Rear)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	DDM(Driver's Door Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	DSM(Driver's Seat Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	HCM(Headlamp Control Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	PAM(Parking Aid Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	PDM(Passenger's Door Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	RCM(Restraint Control Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	RFA(Remote Function Actuator)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	SRM(Speech Recognition Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	TCM(Transmission Control Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	TRM(Trailer Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)			V	V	V												V																																
MONDEO	2007 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2003 MY	2.0L DIESEL	SYSTEM SEARCH																																																
MONDEO	2003 MY	2.0L DIESEL	PCM(PowerTrain Control Module)			V	V	V	V																																										
MONDEO	2003 MY	2.0L DIESEL	TCM(Transmission Control Module)			V	V	V																																												
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)			V	V	V																			V																									
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)			V	V	V	V																		V																									
MONDEO	2003 MY	2.0L DIESEL	CSM(Central Security Module)			V	V																																													
MONDEO	2003 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)			V	V	V	V																																										
MONDEO	2003 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)			V	V	V	V																																										
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)			V	V	V	V										V																																
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)			V	V	V	V										V																																
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)			V	V	V	V																																										
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)			V	V	V	V																																										
MONDEO	2003 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)			V	V	V	V																																										
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)			V	V	V																																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)			V	V	V																																												
MONDEO	2003 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)			V	V	V																																												
MONDEO	2003 MY	2.0L DIESEL	ACM(Audio Control Module)			V	V	V																																												
MONDEO	2003 MY	2.0L DIESEL	CDP(Compact Disc Player)			V	V	V																																												
MONDEO	2003 MY	2.0L DIESEL	GDM(Generic Display Module)			V	V	V																																												
MONDEO	2003 MY	2.0L DIESEL	NAV(Navigation System)			V	V	V																																												
MONDEO	2003 MY	2.0L DIESEL	RETM(Rear Entertainment Module)			V	V	V																																												
MONDEO	2003 MY	2.0L DIESEL	SRM(Speech Recognition Module)			V	V	V																																												
MONDEO	2003 MY	2.0L DIESEL	ICU(Injector Control Unit)					V																																												
MONDEO	2003 MY	2.0L DIESEL	PATS(Passive Anti Theft System)			V	V	V	V																																											
MONDEO	2002 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2002 MY	2.0L DIESEL	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	2002 MY	2.0L DIESEL	TCM(Transmission Control Module)			V	V	V																																												
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)			V	V	V																		V																										
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)			V	V	V	V																	V																										
MONDEO	2002 MY	2.0L DIESEL	CSM(Central Security Module)			V	V																																													
MONDEO	2002 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)			V	V	V	V																																											
MONDEO	2002 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)			V	V	V	V																																											
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)			V	V	V	V										V																																	
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)			V	V	V	V										V																																	
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)			V	V	V	V																																											
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)			V	V	V	V																																											
MONDEO	2002 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)			V	V	V	V																																											
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)			V	V	V																																												
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)			V	V	V																																												
MONDEO	2002 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)			V	V	V																																												
MONDEO	2002 MY	2.0L DIESEL	ACM(Audio Control Module)			V	V	V																																												
MONDEO	2002 MY	2.0L DIESEL	CDP(Compact Disc Player)			V	V	V																																												
MONDEO	2002 MY	2.0L DIESEL	GDM(Generic Display Module)			V	V	V																																												
MONDEO	2002 MY	2.0L DIESEL	NAV(Navigation System)			V	V	V																																												
MONDEO	2002 MY	2.0L DIESEL	RETM(Rear Entertainment Module)			V	V	V																																												
MONDEO	2002 MY	2.0L DIESEL	SRM(Speech Recognition Module)			V	V	V																																												
MONDEO	2002 MY	2.0L DIESEL	ICU(Injector Control Unit)					V																																												
MONDEO	2002 MY	2.0L DIESEL	PATS(Passive Anti Theft System)			V	V	V	V																																											
MONDEO	2002 MY	2.0L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2002 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	2002 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)			V	V	V	V																																											
MONDEO	2002 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)			V	V	V	V																																											
MONDEO	2002 MY	2.0L GASOLINE	GEM(Generic Electronic Module)			V	V	V	V										V																																	
MONDEO	2002 MY	2.0L GASOLINE	HCM(Headlamp Control Module)			V	V	V																																												
MONDEO	2002 MY	2.0L GASOLINE	RCM(Restraint Control Module)			V	V	V	V																																											
MONDEO	2001 MY	2.0L DIESEL	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	2001 MY	2.0L DIESEL	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)			V	V	V	V																		V																									
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)			V	V	V																			V																									
MONDEO	2001 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)			V	V	V												V																																
MONDEO	2001 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)			V	V	V	V																																											
MONDEO	2001 MY	2.0L DIESEL	GEM(Generic Electronic Module)			V	V	V	V										V																																	
MONDEO	2001 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)			V	V	V	V																																											
MONDEO	2001 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)			V	V	V	V																																											
MONDEO	2001 MY	2.0L DIESEL	RCM(Restraint Control Module)			V	V	V																																												
MONDEO	2001 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)			V	V	V																																												
MONDEO	2001 MY	2.0L DIESEL	ACM(Audio Control Module)			V	V	V																																												
MONDEO	2001 MY	2.0L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2001 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	2001 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)			V	V	V	V																																											
MONDEO	2001 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)			V	V	V	V																																											
MONDEO	2001 MY	2.0L GASOLINE	GEM(Generic Electronic Module)			V	V	V	V										V																																	
MONDEO	2001 MY	2.0L GASOLINE	HCM(Headlamp Control Module)			V	V	V																																												
MONDEO	2001 MY	2.0L GASOLINE	RCM(Restraint Control Module)			V	V	V	V																																											
MONDEO	2000 MY	1.8L	SYSTEM SEARCH																																																	
MONDEO	2000 MY	1.8L	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	2000 MY	1.8L	ABS(Anti-Lock Brake System)			V	V	V					V																																							
MONDEO	2000 MY	1.8L	CSM(Central Security Module)			V	V	V					V																																							
MONDEO	2000 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2000 MY	1.8L DIESEL	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	2000 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)			V	V	V					V																																							
MONDEO	2000 MY	1.8L DIESEL	CSM(Central Security Module)			V	V	V					V																																							
MONDEO	2000 MY	1.8L DIESEL	Passive Antitheft			V	V	V	V				V																																							
MONDEO	2000 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)			V	V																																													
MONDEO	2000 MY	2.0L	SYSTEM SEARCH																																																	
MONDEO	2000 MY	2.0L	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	2000 MY	2.0L	ABS(Anti-Lock Brake System)			V	V	V					V																																							
MONDEO	2000 MY	2.0L	CSM(Central Security Module)			V	V	V					V																																							
MONDEO	2000 MY	2.5L	SYSTEM SEARCH																																																	
MONDEO	2000 MY	2.5L	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	2000 MY	2.5L	ABS(Anti-Lock Brake System)			V	V	V					V																																							
MONDEO	2000 MY	2.5L	CSM(Central Security Module)			V	V	V					V																																							
MONDEO	1999 MY	1.8L	SYSTEM SEARCH																																																	
MONDEO	1999 MY	1.8L	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	1999 MY	1.8L	ABS(Anti-Lock Brake System)			V	V	V					V																																							
MONDEO	1999 MY	1.8L	CSM(Central Security Module)			V	V	V					V																																							
MONDEO	1999 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	1999 MY	1.8L DIESEL	PCM(PowerTrain Control Module)			V	V	V	V																																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MONDEO	1999 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)			V	V	V					V																																							
MONDEO	1999 MY	1.8L DIESEL	CSM(Central Security Module)			V	V	V					V																																							
MONDEO	1999 MY	1.8L DIESEL	Passive Antitheft			V	V	V	V				V																																							
MONDEO	1999 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)			V	V																																													
MONDEO	1999 MY	2.0L	SYSTEM SEARCH																																																	
MONDEO	1999 MY	2.0L	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	1999 MY	2.0L	ABS(Anti-Lock Brake System)			V	V	V					V																																							
MONDEO	1999 MY	2.0L	CSM(Central Security Module)			V	V	V					V																																							
MONDEO	1999 MY	2.5L	SYSTEM SEARCH																																																	
MONDEO	1999 MY	2.5L	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	1999 MY	2.5L	ABS(Anti-Lock Brake System)			V	V	V					V																																							
MONDEO	1999 MY	2.5L	CSM(Central Security Module)			V	V	V					V																																							
MONDEO	1998 MY	1.8L	SYSTEM SEARCH																																																	
MONDEO	1998 MY	1.8L	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	1998 MY	1.8L	ABS(Anti-Lock Brake System)			V	V	V					V																																							
MONDEO	1998 MY	1.8L	CSM(Central Security Module)			V	V	V					V																																							
MONDEO	1998 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	1998 MY	1.8L DIESEL	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	1998 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)			V	V	V					V																																							
MONDEO	1998 MY	1.8L DIESEL	CSM(Central Security Module)			V	V	V					V																																							
MONDEO	1998 MY	1.8L DIESEL	Passive Antitheft			V	V	V	V				V																																							
MONDEO	1998 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)			V	V																																													
MONDEO	1998 MY	2.0L	SYSTEM SEARCH																																																	
MONDEO	1998 MY	2.0L	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	1998 MY	2.0L	ABS(Anti-Lock Brake System)			V	V	V					V																																							
MONDEO	1998 MY	2.0L	CSM(Central Security Module)			V	V	V					V																																							
MONDEO	1998 MY	2.5L	SYSTEM SEARCH																																																	
MONDEO	1998 MY	2.5L	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	1998 MY	2.5L	ABS(Anti-Lock Brake System)			V	V	V					V																																							
MONDEO	1998 MY	2.5L	CSM(Central Security Module)			V	V	V					V																																							
MONDEO	1997 MY	1.8L	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	1997 MY	1.8L	ABS(Anti-Lock Brake System)			V	V	V																																												
MONDEO	1997 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	1997 MY	1.8L DIESEL	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	1997 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)			V	V	V																																												
MONDEO	1997 MY	1.8L DIESEL	Passive Antitheft			V	V	V	V																																											
MONDEO	1997 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)			V	V																																													
MONDEO	1997 MY	2.0L	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	1997 MY	2.0L	ABS(Anti-Lock Brake System)			V	V	V																																												
MONDEO	1997 MY	2.5L	PCM(PowerTrain Control Module)			V	V	V	V																																											
MONDEO	1997 MY	2.5L	ABS(Anti-Lock Brake System)			V	V	V																																												
MOUNTAINEER	2010 MY	4.6L	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MOUNTAINEER	2010 MY	4.6L	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V		V	V	V	V																									
MOUNTAINEER	2010 MY	4.6L	TCM(Transmission Control Module)			V	V	V							V	V							V	V	V	V												V													
MOUNTAINEER	2010 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V						V																																				
MOUNTAINEER	2010 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V												V	V											
MOUNTAINEER	2010 MY	4.6L	ACM(Audio Control Module)			V	V	V							V					V																															
MOUNTAINEER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																															
MOUNTAINEER	2010 MY	4.6L	GPSM(Global Positioning System Module)			V	V	V												V																															
MOUNTAINEER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)			V	V	V																																											
MOUNTAINEER	2010 MY	4.6L	DSM(Driver's Seat Module)			V	V	V							V																																				
MOUNTAINEER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V							V				V													V																			
MOUNTAINEER	2010 MY	4.6L	IC(Instrument Cluster)			V	V	V	V						V																											V										
MOUNTAINEER	2010 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V							V																																				
MOUNTAINEER	2010 MY	4.6L	PAM(Parking Aid Module)			V	V	V																																											
MOUNTAINEER	2010 MY	4.6L	PRB(Power Running Board)			V	V	V	V						V																																				
MOUNTAINEER	2010 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V						V																						V														
MOUNTAINEER	2010 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V																																											
MOUNTAINEER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V																																										
MOUNTAINEER	2009 MY	4.6L	SYSTEM SEARCH																																																
MOUNTAINEER	2009 MY	4.6L	PCM(Powertrain Control Module)			V	V	V						V	V	V				V	V		V	V	V	V																									
MOUNTAINEER	2009 MY	4.6L	TCM(Transmission Control Module)			V	V	V							V	V							V	V	V	V												V													
MOUNTAINEER	2009 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V						V																																				
MOUNTAINEER	2009 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V												V	V											
MOUNTAINEER	2009 MY	4.6L	ACM(Audio Control Module)			V	V	V							V					V																															
MOUNTAINEER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																															
MOUNTAINEER	2009 MY	4.6L	GPSM(Global Positioning System Module)			V	V	V												V																															
MOUNTAINEER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)			V	V	V																																											
MOUNTAINEER	2009 MY	4.6L	DSM(Driver's Seat Module)			V	V	V							V																																				
MOUNTAINEER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V							V				V													V																			
MOUNTAINEER	2009 MY	4.6L	IC(Instrument Cluster)			V	V	V	V						V																											V										
MOUNTAINEER	2009 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V							V																																				
MOUNTAINEER	2009 MY	4.6L	PAM(Parking Aid Module)			V	V	V																																											
MOUNTAINEER	2009 MY	4.6L	PRB(Power Running Board)			V	V	V	V						V																																				
MOUNTAINEER	2009 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V						V																						V														
MOUNTAINEER	2009 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V																																											
MOUNTAINEER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V																																										
MUSTANG	4.0L V6 SOHC			SYSTEM SEARCH																																															
MUSTANG	4.0L V6 SOHC			PCM(Powertrain Control Module)		V	V	V												V	V		V	V	V	V																									
MUSTANG	4.0L V6 SOHC			ABS(Anti-Lock Brake System)		V	V	V	V						V												V												V	V											
MUSTANG	4.0L V6 SOHC			ACM(Audio Control Module)		V	V	V							V																																				
MUSTANG	4.0L V6 SOHC			APIM(Accessory Protocol Interface Module)		V	V	V							V																																				
MUSTANG	4.0L V6 SOHC			GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V						V				V													V																			
MUSTANG	4.0L V6 SOHC			RCM(Restraint Control Module)		V	V	V																																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
MUSTANG	4.0L V6 SOHC			SDARS(Satellite Digital Audio Receiver System)		V	V	V	V																																											
MUSTANG	4.0L V6 SOHC			IC(Instrument Cluster)		V	V	V	V						V																											V										
TAURUS	2011 MY	3.5L	SYSTEM SEARCH																																																	
TAURUS	2011 MY	3.5L	PCM(PowerTrain Control Module)			V	V	V	V					V	V	V				V	V		V	V	V	V																										
TAURUS	2011 MY	3.5L	4X4(4x4 Control Module)			V	V	V	V						V																																						
TAURUS	2011 MY	3.5L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V																										
TAURUS	2011 MY	3.5L	ACM(Audio Control Module)			V	V	V							V					V									V																								
TAURUS	2011 MY	3.5L	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																	
TAURUS	2011 MY	3.5L	C-CM(Cruise Control Module)			V	V	V	V											V														V																			
TAURUS	2011 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)			V	V	V	V																																												
TAURUS	2011 MY	3.5L	DDM(Driver's Door Module)			V	V	V	V																																												
TAURUS	2011 MY	3.5L	DSM(Driver's Seat Module)			V	V	V	V						V																																						
TAURUS	2011 MY	3.5L	DSP(Digital Signal Processing Module)			V	V	V												V																																	
TAURUS	2011 MY	3.5L	FCIM(Front Controls Interface Module)			V	V	V							V					V																																	
TAURUS	2011 MY	3.5L	FDIM(Front Display Interface Module)			V	V	V																																													
TAURUS	2011 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V																							V	V																				
TAURUS	2011 MY	3.5L	GPSM(Global Positioning System Module)			V	V	V							V					V																																	
TAURUS	2011 MY	3.5L	HCM(Headlamp Control Module)			V	V	V	V											V																																	
TAURUS	2011 MY	3.5L	HCM-2(Headlamp Control Module2)			V	V	V																																													
TAURUS	2011 MY	3.5L	HUD(Head Up Display)			V	V	V												V																																	
TAURUS	2011 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V						V					V																																	
TAURUS	2011 MY	3.5L	ILCM(Interior Lighting Control Module)			V	V	V	V						V																																						
TAURUS	2011 MY	3.5L	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																	
TAURUS	2011 MY	3.5L	OCSM(Occupant Classification System Module)			V	V	V												V																																	
TAURUS	2011 MY	3.5L	PAM(Parking Aid Module)			V	V	V												V																																	
TAURUS	2011 MY	3.5L	PSCM(Power Steering Control Module)			V	V	V												V																																	
TAURUS	2011 MY	3.5L	RCM(Restraint Control Module)			V	V	V							V					V																	V																
TAURUS	2011 MY	3.5L	RETM(Rear Entertainment Module)			V	V	V							V																																						
TAURUS	2011 MY	3.5L	RFA(Remote Function Actuator)			V	V	V	V											V																																	
TAURUS	2011 MY	3.5L	SASM(Steering Angle Sensor Module)			V	V	V							V																																						
TAURUS	2011 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V											V																																	
TAURUS	2011 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V											V																																	
TAURUS	2010 MY	3.5L	SYSTEM SEARCH																																																	
TAURUS	2010 MY	3.5L	PCM(PowerTrain Control Module)			V	V	V	V					V	V	V				V	V		V	V	V	V																										
TAURUS	2010 MY	3.5L	4X4(4x4 Control Module)			V	V	V	V						V																																						
TAURUS	2010 MY	3.5L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V																										
TAURUS	2010 MY	3.5L	ACM(Audio Control Module)			V	V	V							V					V									V																								
TAURUS	2010 MY	3.5L	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																	
TAURUS	2010 MY	3.5L	C-CM(Cruise Control Module)			V	V	V	V											V														V																			
TAURUS	2010 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)			V	V	V	V																																												
TAURUS	2010 MY	3.5L	DDM(Driver's Door Module)			V	V	V	V																																												
TAURUS	2010 MY	3.5L	DSM(Driver's Seat Module)			V	V	V	V						V																																						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
TAURUS	2010 MY	3.5L	DSP(Digital Signal Processing Module)			V	V	V												V																																
TAURUS	2010 MY	3.5L	FCIM(Front Controls Interface Module)			V	V	V							V					V																																
TAURUS	2010 MY	3.5L	FDIM(Front Display Interface Module)			V	V	V																																												
TAURUS	2010 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V																							V	V																			
TAURUS	2010 MY	3.5L	GPSM(Global Positioning System Module)			V	V	V							V					V																																
TAURUS	2010 MY	3.5L	HCM(Headlamp Control Module)			V	V	V	V											V																																
TAURUS	2010 MY	3.5L	HCM-2(Headlamp Control Module2)			V	V	V																																												
TAURUS	2010 MY	3.5L	HUD(Head Up Display)			V	V	V												V																																
TAURUS	2010 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V						V					V																																
TAURUS	2010 MY	3.5L	ILCM(Interior Lighting Control Module)			V	V	V	V						V																																					
TAURUS	2010 MY	3.5L	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
TAURUS	2010 MY	3.5L	OCSM(Occupant Classification System Module)			V	V	V												V																																
TAURUS	2010 MY	3.5L	PAM(Parking Aid Module)			V	V	V												V																																
TAURUS	2010 MY	3.5L	PSCM(Power Steering Control Module)			V	V	V												V																																
TAURUS	2010 MY	3.5L	RCM(Restraint Control Module)			V	V	V							V					V																	V															
TAURUS	2010 MY	3.5L	RETM(Rear Entertainment Module)			V	V	V							V																																					
TAURUS	2010 MY	3.5L	RFA(Remote Function Actuator)			V	V	V	V											V																																
TAURUS	2010 MY	3.5L	SASM(Steering Angle Sensor Module)			V	V	V							V																																					
TAURUS	2010 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V											V																																
TAURUS	2010 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V											V																																
TAURUS	2009 MY	3.5L	SYSTEM SEARCH																																																
TAURUS	2009 MY	3.5L	PCM(PowerTrain Control Module)			V	V	V	V					V	V	V				V	V		V	V	V	V																									
TAURUS	2009 MY	3.5L	4X4(4x4 Control Module)			V	V	V	V						V																																					
TAURUS	2009 MY	3.5L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V																									
TAURUS	2009 MY	3.5L	ACM(Audio Control Module)			V	V	V							V					V									V																							
TAURUS	2009 MY	3.5L	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																
TAURUS	2009 MY	3.5L	C-CM(Cruise Control Module)			V	V	V	V											V														V																			
TAURUS	2009 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)			V	V	V	V																																											
TAURUS	2009 MY	3.5L	DDM(Driver's Door Module)			V	V	V	V																																											
TAURUS	2009 MY	3.5L	DSM(Driver's Seat Module)			V	V	V	V						V																																					
TAURUS	2009 MY	3.5L	DSP(Digital Signal Processing Module)			V	V	V												V																																
TAURUS	2009 MY	3.5L	FCIM(Front Controls Interface Module)			V	V	V							V					V																																
TAURUS	2009 MY	3.5L	FDIM(Front Display Interface Module)			V	V	V																																												
TAURUS	2009 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V																							V	V																			
TAURUS	2009 MY	3.5L	GPSM(Global Positioning System Module)			V	V	V							V					V																																
TAURUS	2009 MY	3.5L	HCM(Headlamp Control Module)			V	V	V	V											V																																
TAURUS	2009 MY	3.5L	HCM-2(Headlamp Control Module2)			V	V	V																																												
TAURUS	2009 MY	3.5L	HUD(Head Up Display)			V	V	V												V																																
TAURUS	2009 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V						V					V																																
TAURUS	2009 MY	3.5L	ILCM(Interior Lighting Control Module)			V	V	V	V						V																																					
TAURUS	2009 MY	3.5L	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
TAURUS	2009 MY	3.5L	OCSM(Occupant Classification System Module)			V	V	V												V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
TAURUS	2009 MY	3.5L	PAM(Parking Aid Module)			V	V	V												V																																
TAURUS	2009 MY	3.5L	PSCM(Power Steering Control Module)			V	V	V												V																																
TAURUS	2009 MY	3.5L	RCM(Restraint Control Module)			V	V	V							V					V																		V														
TAURUS	2009 MY	3.5L	RETM(Rear Entertainment Module)			V	V	V							V																																					
TAURUS	2009 MY	3.5L	RFA(Remote Function Actuator)			V	V	V	V											V																																
TAURUS	2009 MY	3.5L	SASM(Steering Angle Sensor Module)			V	V	V							V																																				
TAURUS	2009 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V											V																																
TAURUS	2009 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V											V																																
TAURUS	2008 MY	3.5L	SYSTEM SEARCH																																																
TAURUS	2008 MY	3.5L	PCM(PowerTrain Control Module)			V	V	V	V					V	V	V				V	V		V	V	V	V																									
TAURUS	2008 MY	3.5L	4X4(4x4 Control Module)			V	V	V	V						V																																					
TAURUS	2008 MY	3.5L	ABS(Anti-Lock Brake System)			V	V	V	V						V												V																									
TAURUS	2008 MY	3.5L	ACM(Audio Control Module)			V	V	V							V					V									V																							
TAURUS	2008 MY	3.5L	APIM(Accessory Protocol Interface Module)			V	V	V							V					V																																
TAURUS	2008 MY	3.5L	C-CM(Cruise Control Module)			V	V	V	V											V															V																	
TAURUS	2008 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)			V	V	V	V																																											
TAURUS	2008 MY	3.5L	DDM(Driver's Door Module)			V	V	V	V																																											
TAURUS	2008 MY	3.5L	DSM(Driver's Seat Module)			V	V	V	V						V																																					
TAURUS	2008 MY	3.5L	DSP(Digital Signal Processing Module)			V	V	V												V																																
TAURUS	2008 MY	3.5L	FCIM(Front Controls Interface Module)			V	V	V							V					V																																
TAURUS	2008 MY	3.5L	FDIM(Front Display Interface Module)			V	V	V																																												
TAURUS	2008 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V																							V	V																			
TAURUS	2008 MY	3.5L	GPSM(Global Positioning System Module)			V	V	V							V					V																																
TAURUS	2008 MY	3.5L	HCM(Headlamp Control Module)			V	V	V	V											V																																
TAURUS	2008 MY	3.5L	HCM-2(Headlamp Control Module2)			V	V	V																																												
TAURUS	2008 MY	3.5L	HUD(Head Up Display)			V	V	V												V																																
TAURUS	2008 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V						V					V																																
TAURUS	2008 MY	3.5L	ILCM(Interior Lighting Control Module)			V	V	V	V						V																																					
TAURUS	2008 MY	3.5L	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
TAURUS	2008 MY	3.5L	OCSM(Occupant Classification System Module)			V	V	V												V																																
TAURUS	2008 MY	3.5L	PAM(Parking Aid Module)			V	V	V												V																																
TAURUS	2008 MY	3.5L	PSCM(Power Steering Control Module)			V	V	V												V																																
TAURUS	2008 MY	3.5L	RCM(Restraint Control Module)			V	V	V							V					V																		V														
TAURUS	2008 MY	3.5L	RETM(Rear Entertainment Module)			V	V	V							V																																					
TAURUS	2008 MY	3.5L	RFA(Remote Function Actuator)			V	V	V	V											V																																
TAURUS	2008 MY	3.5L	SASM(Steering Angle Sensor Module)			V	V	V							V																																				
TAURUS	2008 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V											V																																
TAURUS	2008 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V											V																																
TAURUS	1998 MY	SYSTEM SEARCH																																																	
TAURUS	1998 MY	PCM(PowerTrain Control Module)				V	V	V	V																																										
TAURUS	1998 MY	ABS(Anti-Lock Brake System)				V	V	V					V																																						
TAURUS	1998 MY	RCM(Restraint Control Module)				V	V	V					V																																						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
TAURUS	1998 MY	RIM(Remote Immobilizer Module)				V	V	V	V				V																																							
TAURUS	1997 MY	SYSTEM SEARCH																																																		
TAURUS	1997 MY	PCM(PowerTrain Control Module)				V	V	V	V																																											
TAURUS	1997 MY	ABS(Anti-Lock Brake System)				V	V	V					V																																							
TAURUS	1997 MY	RCM(Restraint Control Module)				V	V	V					V																																							
TAURUS	1997 MY	RIM(Remote Immobilizer Module)				V	V	V	V				V																																							
TAURUS	1996 MY	SYSTEM SEARCH																																																		
TAURUS	1996 MY	PCM(PowerTrain Control Module)				V	V	V	V																																											
TAURUS	1996 MY	ABS(Anti-Lock Brake System)				V	V	V					V																																							
TAURUS	1996 MY	RCM(Restraint Control Module)				V	V	V					V																																							
TAURUS	1996 MY	RIM(Remote Immobilizer Module)				V	V	V	V				V																																							
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	SYSTEM SEARCH																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PCM(PowerTrain Control Module)		V	V	V						V	V	V				V	V																															
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	TCM(Transmission Control Module)		V	V	V												V																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ABS(Anti-Lock Brake System)		V	V	V	V											V							V	V																									
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ACM(Audio Control Module)		V	V	V	V						V					V																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	APIM(Accessory Protocol Interface Module)		V	V	V							V					V																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	BEM(Body Electronic Module)		V	V	V	V						V																																						
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	FCIM(Front Controls Interface Module)		V	V	V	V											V																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GPSM(Global Positioning System Module)		V	V	V							V					V																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GWM(Gateway Module A)		V	V	V												V																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	HIM(HVAC Integrated Module)		V	V	V							V																																						
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	IPC(Instrument Panel Control Module)		V	V	V	V						V					V																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PAM(Parking Aid Module)		V	V	V												V																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PSCM(Power Steering Control Module)		V	V	V												V																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	RCM(Restraint Control Module)		V	V	V												V																	V																
TERRITORY	2010~	4.0L GASOLINE	SY	SYSTEM SEARCH																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PCM(Powertrain Control Module)		V	V	V						V	V	V				V	V		V	V	V	V																											
TERRITORY	2010~	4.0L GASOLINE	SY	TCM(Transmission Control Module)		V	V	V																																													
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)		V	V	V	V																																												
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)		V	V	V	V											V							V	V																										
TERRITORY	2010~	4.0L GASOLINE	SY	ACM(Audio Control Module)		V	V	V							V																																						
TERRITORY	2010~	4.0L GASOLINE	SY	PSCM(Power Steering Control Module)		V	V	V												V																																	
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)		V	V	V							V																																						
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)		V	V	V	V						V																																						
TERRITORY	2010~	4.0L GASOLINE	SY	HIM(HVAC Integrated Module)		V	V	V							V																																						
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)		V	V	V							V																																						
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)		V	V	V	V						V					V																																	
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)		V	V	V	V																																												
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)		V	V	V							V													V																									
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)		V	V	V																																													
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)		V	V	V												V																	V																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
TERRITORY	2010~	4.0L GASOLINE	SY	FDIM(Front Display Interface Module)		V	V	V	V						V																																					
TERRITORY	2010~	2.7L DIESEL	SZ	SYSTEM SEARCH																																																
TERRITORY	2010~	2.7L DIESEL	SZ	PCM(Powertrain Control Module)		V	V	V						V	V	V				V	V																						V									
TERRITORY	2010~	2.7L DIESEL	SZ	ABS(Anti-Lock Brake System)		V	V	V	V											V							V	V																									
TERRITORY	2010~	2.7L DIESEL	SZ	ACM(Audio Control Module)		V	V	V							V														V																								
TERRITORY	2010~	2.7L DIESEL	SZ	AWD(All Wheel Drive Module)		V	V	V																																												
TERRITORY	2010~	2.7L DIESEL	SZ	BEM(Body Electronic Module)		V	V	V	V						V																																					
TERRITORY	2010~	2.7L DIESEL	SZ	FDIM(Front Display Interface Module)		V	V	V	V						V																																					
TERRITORY	2010~	2.7L DIESEL	SZ	HIM(HVAC Intergrated Module)		V	V	V							V																																					
TERRITORY	2010~	2.7L DIESEL	SZ	IPC(Instrument Panel Control Module)		V	V	V	V						V					V																																	
TERRITORY	2010~	2.7L DIESEL	SZ	PAM(Parking Aid Module)		V	V	V	V						V																																					
TERRITORY	2010~	2.7L DIESEL	SZ	PSCM(Power Steering Control Module)		V	V	V												V																																	
TERRITORY	2010~	2.7L DIESEL	SZ	RCM(Restraint Control Module)		V	V	V												V																	V															
TERRITORY	2010~	2.7L DIESEL	SZ	TCM(Transmission Control Module)		V	V	V												V	V																																
TERRITORY	2009~2010	SYSTEM SEARCH																																																		
TERRITORY	2009~2010	PCM(PowerTrain Control Module)				V	V	V						V	V	V				V	V																																
TERRITORY	2009~2010	TCM(Transmission Control Module)				V	V	V																																													
TERRITORY	2009~2010	ABS(Anti-Lock Brake System)				V	V	V					V														V																											
TERRITORY	2009~2010	RCM(Restraint Control Module)				V	V	V					V																																								
TERRITORY	2009~2010	BEM(Body Electronic Module)				V	V	V	V				V		V																																						
TERRITORY	2009~2010	IC(Instrument Cluster)				V	V	V	V																																												
TERRITORY	2009~2010	HIM(HVAC Integrated Module)				V	V	V	V				V		V																																						
TERRITORY	2009~2010	ACM(Audio Control Module)				V	V	V												V																																	
TERRITORY	2005~2009	SYSTEM SEARCH																																																		
TERRITORY	2005~2009	PCM(PowerTrain Control Module)				V	V	V						V	V	V				V	V																																
TERRITORY	2005~2009	TCM(Transmission Control Module)				V	V	V																																													
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)				V	V	V					V														V																											
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)				V	V	V	V				V														V																											
TERRITORY	2005~2009	RCM(Restraint Control Module)				V	V	V					V																																								
TERRITORY	2005~2009	BEM(Body Electronic Module)				V	V	V	V				V		V																																						
TERRITORY	2005~2009	IC(Instrument Cluster)				V	V	V	V																																												
TERRITORY	2005~2009	HIM(HVAC Integrated Module)				V	V	V	V				V		V																																						
TERRITORY	2005~2009	ACM(Audio Control Module)				V	V	V												V																																	
TERRITORY	2004~2005	SYSTEM SEARCH																																																		
TERRITORY	2004~2005	PCM(PowerTrain Control Module)				V	V	V						V	V	V				V	V																																
TERRITORY	2004~2005	ABS(Anti-Lock Brake System)				V	V	V	V				V														V																											
TERRITORY	2004~2005	RCM(Restraint Control Module)				V	V	V					V																																								
TERRITORY	2004~2005	BEM(Body Electronic Module)				V	V	V	V						V																																						
TERRITORY	2004~2005	IC(Instrument Cluster)				V	V	V	V																																												
TERRITORY	2004~2005	HIM(HVAC Integrated Module)				V	V	V					V																																								
TERRITORY	2004~2005	HIM(HVAC Integrated Module)				V	V	V					V																																								
TERRITORY	2004~2005	ACM(Audio Control Module)				V	V	V												V																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
TERRITORY	2004~2005	PAM(Parking Aid Module)				V	V	V					V																																							
TRANSIT	1.6L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	1.6L DIESEL	PCM(PowerTrain Control Module)				V	V	V							V					V																								V								
TRANSIT	1.6L DIESEL	ABS(Anti-Lock Brake System)				V	V	V												V																																
TRANSIT	1.6L DIESEL	ACM(Audio Control Module)				V	V	V					V							V																																
TRANSIT	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)				V	V	V												V																																
TRANSIT	1.6L DIESEL	APIM(Accessory Protocol Interface Module)				V	V	V												V																																
TRANSIT	1.6L DIESEL	BCMii(Body Control Module)				V	V	V							V					V																																
TRANSIT	1.6L DIESEL	DDM(Driver's Door Module)				V	V	V																																												
TRANSIT	1.6L DIESEL	FCIM(Front Controls Interface Module)				V	V	V												V																																
TRANSIT	1.6L DIESEL	FDSM(Front Distance Sensing Module)				V	V	V												V																																
TRANSIT	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)				V	V	V	V											V																																
TRANSIT	1.6L DIESEL	GPSM(Global Positioning System Module)				V	V	V												V																																
TRANSIT	1.6L DIESEL	HCM(Headlamp Control Module)				V	V	V												V																																
TRANSIT	1.6L DIESEL	HVAC(Heating Ventilation Air Conditioning)				V	V	V												V																																
TRANSIT	1.6L DIESEL	IPM-B(Image Processing Module B)				V	V	V																																												
TRANSIT	1.6L DIESEL	IPC(Instrument Panel Control Module)				V	V	V	V						V					V																																
TRANSIT	1.6L DIESEL	PAM(Parking Aid Module)				V	V	V							V					V																																
TRANSIT	1.6L DIESEL	PDM(Passenger's Door Module)				V	V	V												V																																
TRANSIT	1.6L DIESEL	PSCM(Power Steering Control Module)				V	V	V												V																																
TRANSIT	1.6L DIESEL	RCM(Restraint Control Module)				V	V	V							V					V																																
TRANSIT	1.6L DIESEL	SASM(Steering Angle Sensor Module)				V	V	V							V					V																																
TRANSIT	1.6L DIESEL	TRM(Trailer Module)				V	V	V	V											V																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)		V	V	V							V	V				V																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)		V	V	V	V																																											
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)		V	V	V												V							V																										
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)		V	V	V					V																																							
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)		V	V	V					V																																							
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)		V	V	V																																												
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)		V	V	V																																												
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)		V	V	V	V				V																																							
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)				V																																												
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)		V	V	V	V																																											
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)		V	V	V																													V															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)		V	V	V	V				V																																							
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)		V	V	V							V	V				V																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)		V	V	V												V							V																										
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)		V	V	V							V																																					
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)		V	V	V	V																																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)		V	V	V							V																																					
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)		V	V	V	V																																											
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)		V	V	V																													V														
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)		V	V													V																																
TRANSIT	2.0L	SYSTEM SEARCH																																																		
TRANSIT	2.0L	PCM(PowerTrain Control Module)				V	V	V	V																																											
TRANSIT	2.0L	PATS(Passive Anti Theft System)																																																		
TRANSIT	2.0L	ASM(Auto Shift Manual)				V	V	V																																												
TRANSIT	2.0L	ABS(Anti-Lock Brake System)				V	V	V					V																																							
TRANSIT	2.0L	HEC(Hybrid Electrical Cluster)				V	V	V																																												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SYSTEM SEARCH																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PCM(PowerTrain Control Module)		V	V	V												V																								V		V						
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)		V	V	V												V																											V	V	V	V	V
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ACM(Audio Control Module)		V	V	V					V							V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	APIM(Accessory Protocol Interface Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	AHCM(Auxiliary Heater Control Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	CCMii(Cruise Control Module)		V	V	V	V											V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FCDIM(Front Control/Display Interface Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	GPSM(Global Positioning System Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	HCM(Headlamp Control Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-A(Image Processing Module A)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-B(Image Processing Module B)		V	V	V																																												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FFH(Fuel Fired Coolant Heating Module)		V	V	V																																												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)		V	V	V	V											V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PRB(Power Running Board)		V	V	V	V						V																																					
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)		V	V	V																																												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SRM(Speech Recognition Module)		V	V													V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SASM(Steering Angle Sensor Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TBC(Trailer Brake Control Module)		V	V	V																																												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TRM(Trailer Module)		V	V	V	V						V					V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SYSTEM SEARCH																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PCM(PowerTrain Control Module)		V	V	V												V																								V		V						
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)		V	V	V												V																											V	V	V	V	V
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ACM(Audio Control Module)		V	V	V					V							V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	APIM(Accessory Protocol Interface Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	AHCM(Auxiliary Heater Control Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	CCMii(Cruise Control Module)		V	V	V	V											V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FCDIM(Front Control/Display Interface Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	GPSM(Global Positioning System Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	HCM(Headlamp Control Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-A(Image Processing Module A)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-B(Image Processing Module B)		V	V	V																																												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FFH(Fuel Fired Coolant Heating Module)		V	V	V																																												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)		V	V	V	V											V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PRB(Power Running Board)		V	V	V	V						V																																					
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)		V	V	V																																												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SRM(Speech Recognition Module)		V	V													V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SASM(Steering Angle Sensor Module)		V	V	V												V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TBC(Trailer Brake Control Module)		V	V	V																																												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TRM(Trailer Module)		V	V	V	V						V					V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	SYSTEM SEARCH																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)		V	V	V	V																																											
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)		V	V	V							V	V				V																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PATS(Passive Anti Theft System)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ASM(Auto Shift Manual)		V	V	V																																												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)		V	V	V					V																																								
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)		V	V	V												V																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)		V	V	V	V				V																																								
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)		V	V	V																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	HEC(Hybrid Electrical Cluster)		V	V	V																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	IPC(Instrument Panel Control Module)		V	V	V							V					V																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	BCMii(Body Control Module)		V	V	V							V					V																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	CSM(Central Security Module)		V	V	V					V																																								
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ACM(Audio Control Module)		V	V								V					V																																	
TRANSIT	2.3L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)				V	V	V	V																																												
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)				V	V	V							V	V				V																																		
TRANSIT	2.3L DIESEL	PATS(Passive Anti Theft System)																																																		
TRANSIT	2.3L DIESEL	ASM(Auto Shift Manual)				V	V	V																																													
TRANSIT	2.3L DIESEL	ABS(Anti-Lock Brake System)				V	V	V												V																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
TRANSIT	2.3L DIESEL	RCM(Restraint Control Module)				V	V	V																																												
TRANSIT	2.3L DIESEL	HEC(Hybrid Electrical Cluster)				V	V	V																																												
TRANSIT	2.3L DIESEL	IPC(Instrument Panel Control Module)				V	V	V							V					V																																
TRANSIT	2.3L DIESEL	BCMii(Body Control Module)				V	V	V							V					V																																
TRANSIT	2.3L DIESEL	ACM(Audio Control Module)				V	V								V					V																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)			V	V	V	V						V	V				V	V																															
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)			V	V	V												V							V																				V	V	V	V	V
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)			V	V	V					V							V																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	BCMii(Body Control Module)			V	V	V	V											V																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)			V	V																																												
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	IPC(Instrument Panel Control Module)			V	V	V												V																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)			V	V	V												V																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)			V	V	V																																												
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)			V	V													V																																
TRANSIT	2.4L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)				V	V	V	V																																											
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)				V	V	V							V	V				V																																
TRANSIT	2.4L DIESEL	PATS(Passive Anti Theft System)																																																		
TRANSIT	2.4L DIESEL	ASM(Auto Shift Manual)				V	V	V																																												
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)				V	V	V					V																																							
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)				V	V	V												V																																
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)				V	V	V	V				V																																							
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)				V	V	V																																												
TRANSIT	2.4L DIESEL	HEC(Hybrid Electrical Cluster)				V	V	V																																												
TRANSIT	2.4L DIESEL	IPC(Instrument Panel Control Module)				V	V	V							V					V																																
TRANSIT	2.4L DIESEL	BCMii(Body Control Module)				V	V	V							V					V																																
TRANSIT	2.4L DIESEL	CSM(Central Security Module)				V	V	V					V																																							
TRANSIT	2.4L DIESEL	ACM(Audio Control Module)				V	V								V					V																																
TRANSIT	2.5L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)				V	V	V	V																																											
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)				V	V	V	V																																											
TRANSIT	2.5L DIESEL	PATS(Passive Anti Theft System)																																																		
TRANSIT	2.5L DIESEL	ASM(Auto Shift Manual)				V	V	V																																												
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)			V	V	V					V																																							
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)			V	V	V					V																																							
TRANSIT	2.5L DIESEL	RCM(Restraint Control Module)				V	V	V	V				V																																							
TRANSIT	2.5L DIESEL	HEC(Hybrid Electrical Cluster)				V	V	V																																												
TRANSIT	2.5L DIESEL	CSM(Central Security Module)				V	V	V					V																																							
TRANSIT	2.5L DIESEL	Passive Antitheft				V	V	V	V																																											
TRANSIT	2.5L DIESEL	RIM(Remote Immobilizer Module)				V	V																																													
TRANSIT	2.5L DIESEL	ACM(Audio Control Module)				V	V								V					V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
TRANSIT	3.2L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)				V	V	V	V																																											
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)				V	V	V												V																																
TRANSIT	3.2L DIESEL	ABS(Anti-Lock Brake System)				V	V	V												V																																
TRANSIT	3.2L DIESEL	ACM(Audio Control Module)				V	V													V																																
TRANSIT	3.2L DIESEL	BCMii(Body Control Module)				V	V	V							V					V																																
TRANSIT	3.2L DIESEL	FFH(Fuel Fired Coolant Heating Module)				V	V	V																																												
TRANSIT	3.2L DIESEL	IPC(Instrument Panel Control Module)				V	V	V												V																																
TRANSIT	3.2L DIESEL	PAM(Parking Aid Module)				V	V	V												V																																
TRANSIT	3.2L DIESEL	RCM(Restraint Control Module)				V	V	V																																												
TRANSIT	3.2L DIESEL	SRM(Speech Recognition Module)				V	V													V																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)		V	V	V							V	V				V																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)		V	V	V	V																																											
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)		V	V	V												V							V																										
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)		V	V	V					V																																								
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)		V	V	V					V																																								
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)		V	V	V																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)		V	V	V																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)		V	V	V																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)				V																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)		V	V	V	V																																												
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)		V	V	V																													V																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)		V	V	V	V				V																																								
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																																																	
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)		V	V	V							V	V				V																																		
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)		V	V	V												V							V																											
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)		V	V	V							V																																						
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)		V	V	V	V																																												
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)		V	V	V							V																																						
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)		V	V	V	V																																												
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)		V	V	V																													V																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)		V	V													V																																		
RANGER	2.2 Diesel	SYSTEM SEARCH																																																			
RANGER	2.2 Diesel	PCM(PowerTrain Control Module)				V	V	V	V						V					V	V																						V		V								
RANGER	2.2 Diesel	ABS(Anti-Lock Brake System)				V	V	V	V											V							V																											
RANGER	2.2 Diesel	ACM(Audio Control Module)				V	V	V	V						V					V									V																									
RANGER	2.2 Diesel	BCMii(Body Control Module)				V	V	V	V											V																																		
RANGER	2.2 Diesel	DDM(Driver's Door Module)				V	V	V																																													
RANGER	2.2 Diesel	FCDIM(Front Control/Display Interface Module)				V	V	V	V											V																																		
RANGER	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)				V	V	V	V																																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
RANGER	2.2 Diesel	IPC(Instrument Panel Control Module)				V	V	V	V						V					V																																
RANGER	2.2 Diesel	PAM(Parking Aid Module)				V	V	V							V					V																																
RANGER	2.2 Diesel	PDM(Passenger's Door Module)				V	V	V	V						V					V																																
RANGER	2.2 Diesel	RCM(Restraint Control Module)				V	V	V												V																	V														
RANGER	2.2 Diesel	SRM(Speech Recognition Module)				V	V	V												V																																
RANGER	2.2 Diesel	TBM(Tracking And Blocking Module)				V	V	V																																												
RANGER	2.2 Diesel	TCM(Transmission Control Module)				V	V	V							V	V				V	V																															
RANGER	2.2 Diesel	TCM(Transmission Control Module)				V		V	V																																											
RANGER	2.2 Diesel	TCM(Transmission Control Module)				V		V												V																																
RANGER	2.2 Diesel	TRM(Trailer Module)				V	V	V												V																																
RANGER	2.2 Diesel	PATS(Passive anti theft system)-BETA																																																		
RANGER	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																																		
RANGER	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)				V	V	V	V																																											
RANGER	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)				V	V	V	V																																											
RANGER	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)				V	V	V	V				V																																							
RANGER	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)				V	V	V					V																																							
RANGER	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)-BETA																																																		
RANGER	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																																		
RANGER	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)				V	V	V	V											V																																
RANGER	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)				V	V	V	V																																											
RANGER	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)				V	V	V	V				V																																							
RANGER	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)				V	V	V					V																																							
RANGER	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)-BETA																																																		
RANGER	3.2 Diesel	~ 2015	SYSTEM SEARCH																																																	
RANGER	3.2 Diesel	~ 2015	PCM(PowerTrain Control Module)			V	V	V	V						V	V				V	V																						V		V								
RANGER	3.2 Diesel	~ 2015	ABS(Anti-Lock Brake System)			V	V	V	V											V							V																										
RANGER	3.2 Diesel	~ 2015	ACM(Audio Control Module)			V	V	V	V						V					V																																	
RANGER	3.2 Diesel	~ 2015	BCMii(Body Control Module)			V	V	V	V											V																																	
RANGER	3.2 Diesel	~ 2015	DDM(Driver's Door Module)			V	V	V																																												
RANGER	3.2 Diesel	~ 2015	FCDIM(Front Control/Display Interface Module)			V	V	V	V																																											
RANGER	3.2 Diesel	~ 2015	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V																																											
RANGER	3.2 Diesel	~ 2015	IPC(Instrument Panel Control Module)			V	V	V	V						V																																					
RANGER	3.2 Diesel	~ 2015	PAM(Parking Aid Module)			V	V	V												V																																
RANGER	3.2 Diesel	~ 2015	PDM(Passenger's Door Module)			V	V	V	V											V																																
RANGER	3.2 Diesel	~ 2015	RCM(Restraint Control Module)			V	V	V												V																	V														
RANGER	3.2 Diesel	~ 2015	SRM(Speech Recognition Module)			V	V	V												V																																
RANGER	3.2 Diesel	~ 2015	TBM(Tracking And Blocking Module)			V	V	V																																											
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)			V		V	V																																											
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)			V		V												V																																
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)			V		V												V																																
RANGER	3.2 Diesel	~ 2015	TRM(Trailer Module)			V	V	V												V																																
RANGER	3.2 Diesel	~ 2015	PATS(Passive anti theft system)-BETA																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
RANGER	3.2 Diesel	2015 ~	SYSTEM SEARCH																																																
RANGER	3.2 Diesel	2015 ~	PCM(PowerTrain Control Module)			V	V	V	V						V					V																								V							
RANGER	3.2 Diesel	2015 ~	TCM(Transmission Control Module)			V	V	V												V			V	V	V	V																									
RANGER	3.2 Diesel	2015 ~	ABS(Anti-Lock Brake System)			V	V	V	V						V					V							V																									
RANGER	3.2 Diesel	2015 ~	ACM(Audio Control Module)			V	V	V	V											V																																
RANGER	3.2 Diesel	2015 ~	APIM(Accessory Protocol Interface Module)			V	V	V	V						V					V																																
RANGER	3.2 Diesel	2015 ~	ATCM(All Terrain Control Module)			V	V	V												V																																
RANGER	3.2 Diesel	2015 ~	BCM(Body Control Module)			V	V	V	V						V					V										V																						
RANGER	3.2 Diesel	2015 ~	C-CM(Cruise Control Module)			V	V	V												V														V																		
RANGER	3.2 Diesel	2015 ~	DDM(Driver's Door Module)			V	V	V							V					V																																
RANGER	3.2 Diesel	2015 ~	FCDIM(Front Control/Display Interface Module)			V	V	V	V						V					V																																
RANGER	3.2 Diesel	2015 ~	FCIM(Front Controls Interface Module)			V	V	V	V						V					V																																
RANGER	3.2 Diesel	2015 ~	GPSM(Global Positioning System Module)			V	V	V							V					V																																
RANGER	3.2 Diesel	2015 ~	GWM(Gateway Module A)			V	V	V												V																																
RANGER	3.2 Diesel	2015 ~	HCM(Headlamp Control Module)			V	V	V							V					V																																
RANGER	3.2 Diesel	2015 ~	HUD(Head Up Display)			V	V	V							V					V																																
RANGER	3.2 Diesel	2015 ~	IPC(Instrument Panel Control Module)			V	V	V	V						V					V																																
RANGER	3.2 Diesel	2015 ~	IPM-A(Image Processing Module A)			V	V	V							V					V																																
RANGER	3.2 Diesel	2015 ~	PAM(Parking Aid Module)			V	V	V							V					V																																
RANGER	3.2 Diesel	2015 ~	PDM(Passenger's Door Module)			V	V	V							V					V																																
RANGER	3.2 Diesel	2015 ~	PSCM(Power Steering Control Module)			V	V	V							V					V																																
RANGER	3.2 Diesel	2015 ~	RCM(Restraint Control Module)			V	V	V							V					V																	V														
RANGER	3.2 Diesel	2015 ~	RGTM(Rear Gate/Trunk Module)			V	V	V							V					V																																
RANGER	3.2 Diesel	2015 ~	RTM(Radio Transceiver Module)			V	V	V							V					V																																
RANGER	3.2 Diesel	2015 ~	SCCM(Streering Colume Control Module)			V	V	V							V					V																																
RANGER	3.2 Diesel	2015 ~	TCU(Telemetic Control Unit Module)			V	V	V							V					V																																
RANGER	3.2 Diesel	2015 ~	TRM(Trailer Module)			V	V	V												V																																
RANGER	2.5 Gasoline	SYSTEM SEARCH																																																	
RANGER	2.5 Gasoline	PCM(PowerTrain Control Module)				V	V	V	V					V	V	V				V																																
RANGER	2.5 Gasoline	ABS(Anti-Lock Brake System)				V	V	V	V											V							V																									
RANGER	2.5 Gasoline	ACM(Audio Control Module)				V	V	V	V						V					V									V																							
RANGER	2.5 Gasoline	BCMii(Body Control Module)				V	V	V	V											V																																
RANGER	2.5 Gasoline	DDM(Driver's Door Module)				V	V	V																																												
RANGER	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)				V	V	V	V											V																																
RANGER	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)				V	V	V	V																																											
RANGER	2.5 Gasoline	IPC(Instrument Panel Control Module)				V	V	V	V						V					V																																
RANGER	2.5 Gasoline	PAM(Parking Aid Module)				V	V	V							V					V																																
RANGER	2.5 Gasoline	PDM(Passenger's Door Module)				V	V	V	V						V					V																																
RANGER	2.5 Gasoline	RCM(Restraint Control Module)				V	V	V												V																	V														
RANGER	2.5 Gasoline	SRM(Speech Recognition Module)				V	V	V												V																																
RANGER	2.5 Gasoline	TBM(Tracking And Blocking Module)				V	V	V																																												
RANGER	2.5 Gasoline	TCM(Transmission Control Module)				V		V	V																																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
RANGER	2.5 Gasoline	TCM(Transmission Control Module)				V		V												V																																
RANGER	2.5 Gasoline	TCM(Transmission Control Module)				V		V												V																																
RANGER	2.5 Gasoline	TRM(Trailer Module)				V	V	V												V																																
RANGER	2.5 Gasoline	PATS(Passive anti theft system)-BETA																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	PCM(PowerTrain Control Module)				V	V	V	V																																											
BETA-TEST	FOCUS-1.6L Zetec Rocam	ABS(Anti-Lock Brake System)				V	V	V	V																																											
BETA-TEST	FOCUS-1.6L Zetec Rocam	EATC(Electronic Automatic Temperature Control)				V	V	V	V																																											
BETA-TEST	FOCUS-1.6L Zetec Rocam	GEM(Generic Electronic Module)				V	V	V	V										V																																	
BETA-TEST	FOCUS-1.6L Zetec Rocam	HCM(Headlamp Control Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L Zetec Rocam	MC(Message Center)				V	V	V	V																																											
BETA-TEST	FOCUS-1.6L Zetec Rocam	RCM(Restraint Control Module)				V	V	V	V																																											
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)				V	V	V												V																																
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ACM(Audio Control Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CDP(Compact Disc Player)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CMR(Camera Module Rear)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	D_DCU(Driver Door Control Unit)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)				V	V	V							V																																					
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EPS(Electronic Power Steering)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	FFH(Fuel Fired Coolant Heating Module)				V	V	V							V																																					
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	HCM(Headlamp Control Module)				V	V	V							V																																					
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	IC(Instrument Cluster)				V	V	V	V																																											
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PAM(Parking Aid Module)				V	V	V							V																																					
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PDM(Passenger's Door Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RCM(Restraint Control Module)				V	V	V																													V																
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RETM(Rear Entertainment Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RKE(Remote Keyless Entry)				V	V	V							V																																					
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GDM(Generic Display Module)				V	V	V							V																																					
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	NAV(Navigation System)				V	V	V							V																																					
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RL_DCU(Rear Left Door Control Unit)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RR_DCU(Rear Right Door Control Unit)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)				V	V	V							V																																					
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	TCM(Transmission Control Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PCM(PowerTrain Control Module)				V	V	V							V	V				V																						V										
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ABS(Anti-Lock Brake System)				V	V	V	V																		V																										
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ACM(Audio Control Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CDP(Compact Disc Player)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CMR(Camera Module Rear)				V	V	V																																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	D_DCU(Driver Door Control Unit)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EATC(Electronic Automatic Temperature Control)				V	V	V	V																																											
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EPS(Electronic Power Steering)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FACM(Fuel Additive Control Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	GEM(Generic Electronic Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	HCM(Headlamp Control Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	IC(Instrument Cluster)				V	V	V	V																																											
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PAM(Parking Aid Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PDM(Passenger's Door Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RCM(Restraint Control Module)				V	V	V																													V															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RETM(Rear Entertainment Module)				V	V	V																																												
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RKE(Remote Keyless Entry)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PCM(PowerTrain Control Module)				V	V	V						V	V	V																																				
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ABS(Anti-Lock Brake System)				V	V	V	V																																											
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ACM(Audio Control Module)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	CDP(Compact Disc Player)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EPS(Electronic Power Steering)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GDM(Generic Display Module)				V	V	V							V																																					
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GEM(Generic Electronic Module)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	IC(Instrument Cluster)				V	V	V	V																																											
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	NAV(Navigation System)				V	V	V							V																																					
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PAM(Parking Aid Module)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PDM(Passenger's Door Module)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RETM(Rear Entertainment Module)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RKE(Remote Keyless Entry)				V	V	V							V																																					
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SRM(Speech Recognition Module)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	HCM(Headlamp Control Module)				V	V	V																																												
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RCM(Restraint Control Module)				V	V																																													
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	TCM(Transmission Control Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PCM(PowerTrain Control Module)				V	V	V												V																																
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ABS(Anti-Lock Brake System)				V	V	V	V																																											
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ACM(Audio Control Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	CDP(Compact Disc Player)				V	V	V							V																																					
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EPS(Electronic Power Steering)				V	V	V							V																																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM_TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GDM(Generic Display Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GEM(Generic Electronic Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	IC(Instrument Cluster)				V	V	V	V																																											
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	NAV(Navigation System)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PAM(Parking Aid Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PDM(Passenger's Door Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RETM(Rear Entertainment Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RKE(Remote Keyless Entry)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RL_DCU(Rear Left Door Control Unit)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RR_DCU(Rear Right Door Control Unit)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SRM(Speech Recognition Module)				V	V	V							V																																					
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	HCM(Headlamp Control Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RCM(Restraint Control Module)				V	V																														V															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PCM(Powertrain Control Module)				V	V	V	V					V	V	V				V	V																						V									
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ABS(Anti-Lock Brake System)				V	V	V																			V													V												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ACM(Audio Control Module)				V	V	V							V																																					
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	D_DCU(Driver Door Control Unit)				V	V	V	V																																											
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EATC(Electronic Automatic Temperature Control)				V	V	V	V																																											
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EPS(Electronic power steering)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	GEM(Generic Electronic Module)				V	V	V	V						V																																					
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	HCM(Headlamp Control Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	IC(Instrument Cluster)				V	V	V	V						V																										V											
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PAM(Parking Aid Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PDM(Passenger's Door Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RCM(Restraint Control Module)				V	V	V																													V															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RKE(Remote Keyless Entry)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TBM(Tracking and Blocking Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TCM(Transmission Control Module)				V	V	V							V	V																																				
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PATS(Passive Anti Theft System)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PCM(PowerTrain Control Module)				V	V	V	V						V	V				V																																	
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	ABS(Anti-Lock Brake System)				V	V	V	V																		V													V												
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CDP(Compact Disc Player)				V	V	V																																												
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CMR(Camera Module Rear)				V	V	V																																												
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	D_DCU(Driver Door Control Unit)				V	V	V	V																																											
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EATC(Electronic Automatic Temperature Control)				V	V	V																																												
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EPS(Electronic Power Steering)				V	V	V																																												
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FACM(Fuel Additive Control Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	GEM(Generic Electronic Module)				V	V	V																																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	HCM(Headlamp Control Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	IC(Instrument Cluster)				V	V	V	V																																											
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PDM(Passenger's Door Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PAM(Parking Aid Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RCM(Restraint Control Module)				V	V	V																													V															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RETM(Rear Entertainment Module)				V	V	V																																												
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RKE(Remote Keyless Entry)				V	V	V							V																																					
BETA-TEST	FUSION GASOLINE1.4L	SYSTEM SEARCH																																																		
BETA-TEST	FUSION GASOLINE1.4L	PCM(Powertrain Control Module)				V	V	V							V	V				V																																
BETA-TEST	FUSION GASOLINE1.4L	ABS(Anti-Lock Brake System)				V	V	V												V																																
BETA-TEST	FUSION GASOLINE1.4L	ACM(Audio Control Module)				V	V	V												V																																
BETA-TEST	FUSION GASOLINE1.4L	APIM(Accessory Protocol Interface Module)				V	V	V												V										V																						
BETA-TEST	FUSION GASOLINE1.4L	BCMii(Body Control Module)				V	V	V												V																																
BETA-TEST	FUSION GASOLINE1.4L	DDM(Driver's Door Module)				V	V	V												V																																
BETA-TEST	FUSION GASOLINE1.4L	FDSM(Front Distance Sensing Module)				V	V													V																																
BETA-TEST	FUSION GASOLINE1.4L	FCDIM(Front Control/Display Interface Module)				V	V	V	V											V																																
BETA-TEST	FUSION GASOLINE1.4L	GPSM(Global Positioning System Module)				V	V	V												V																																
BETA-TEST	FUSION GASOLINE1.4L	GWM(Gateway Module A)				V	V	V												V																																
BETA-TEST	FUSION GASOLINE1.4L	HVAC(Heating Ventilation Air Conditioning)				V	V	V	V						V					V																																
BETA-TEST	FUSION GASOLINE1.4L	IPC(Instrument Panel Control Module)				V	V	V	V						V					V																																
BETA-TEST	FUSION GASOLINE1.4L	PDM(Passenger's Door Module)				V	V	V												V																																
BETA-TEST	FUSION GASOLINE1.4L	PSCM(Power Steering Control Module)				V	V	V												V																																
BETA-TEST	FUSION GASOLINE1.4L	RCM(Restraint Control Module)				V	V	V												V																																
BETA-TEST	FUSION GASOLINE1.4L	RFA(Remote Function Actuator)				V	V	V												V																																
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)				V	V	V							V	V				V																							V	V								
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)				V	V	V	V					V	V	V				V																																
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	TCM(Transmission Control Module)				V	V	V																																												
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)				V	V	V												V																																
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)				V	V	V	V																																											
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IC(Instrument Cluster)				V	V	V	V						V																																					
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	GEM(Generic Electronic Module)				V	V	V	V																																											
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ACM(Audio Control Module)				V	V	V							V					V																																
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	BCMii(Body Control Module)				V	V	V							V					V																																
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	FCDIM(Front Control/Display Interface Module)				V	V	V	V						V					V																																
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)				V	V	V	V						V					V																																
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IPC(Instrument Panel Control Module)				V	V	V	V						V					V																																
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PSCM(Power Steering Control Module)				V	V	V							V					V																																
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RCM(Retraint Control Module)				V	V	V												V																																
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RFA(Remote Function Actuator)				V	V	V							V					V																																
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SRM(Speech Recognition Module)				V	V	V												V																																
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SYSTEM SEARCH																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)				V	V	V						V	V	V				V																																
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	TCM(Transmission Control Module)				V	V	V																																												
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)				V	V	V	V																																											
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	IC(Instrument Cluster)				V	V	V																																												
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ACM(Audio Control Module)				V	V	V																																												
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)				V	V	V																																												
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)				V	V	V	V																																											
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)				V	V	V												V																																
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)				V	V	V	V																																											
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)				V	V	V																																												
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)				V	V	V																																												
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)				V	V	V	V																																											
BETA-TEST	FIESTA 1.6L DURATEC 16V	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	PCM(PowerTrain Control Module)				V	V	V						V	V	V				V	V		V	V	V	V																										
BETA-TEST	FIESTA 1.6L DURATEC 16V	TCM(Transmission Control Module)				V	V	V																																												
BETA-TEST	FIESTA 1.6L DURATEC 16V	ABS(Anti-Lock Brake System)				V	V	V	V																																											
BETA-TEST	FIESTA 1.6L DURATEC 16V	IC(Instrument Cluster)				V	V	V	V						V																																					
BETA-TEST	FIESTA 1.6L DURATEC 16V	ACM(Audio Control Module)				V	V	V																																												
BETA-TEST	FIESTA 1.6L DURATEC 16V	EATC(Electronic Automatic Temperature Control)				V	V	V	V						V																																					
BETA-TEST	FIESTA 1.6L DURATEC 16V	GEM(Generic Electronic Module)				V	V	V	V						V																																					
BETA-TEST	FIESTA 1.6L DURATEC 16V	SRM(Speech Recognition Module)				V	V	V												V																																
BETA-TEST	FIESTA 1.6L DURATEC 16V	PATS(Passive Anti Theft System)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PCM(PowerTrain Control Module)				V	V	V	V											V																																
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ABS(Anti-Lock Brake System)				V	V	V	V																																											
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ACM(Audio Control Module)				V	V	V																																												
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	EATC(Electronic Automatic Temperature Control)				V	V	V	V																																											
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	GEM(Generic Electronic Module)				V	V	V	V						V																																					
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	IC(Instrument Cluster)				V	V	V	V																																											
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SRM(Speech Recognition Module)				V	V	V												V																																
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PATS(Passive Anti Theft System)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	SYSTEM SEARCH																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PCM(PowerTrain Control Module)				V	V	V	V					V	V	V				V	V																																
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	ABS(Anti-Lock Brake System)				V	V	V	V																																											
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	IC(Instrument Cluster)				V	V	V	V						V																																					
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RCM(Restraint Control Module)				V	V	V																																												
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RKE(Remote Keyless Entry)				V	V	V											V																																	
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	TCM(Transmission Control Module)				V	V	V													V																																
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PATS(Passive Anti Theft System)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	SYSTEM SEARCH																																																		
BETA-TEST	MONDEO-2.0L DIESEL	PCM(PowerTrain Control Module)				V	V	V												V	V																						V									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
BETA-TEST	MONDEO-2.0L DIESEL	ABS(Anti-Lock Brake System)				V	V	V												V							V																										
BETA-TEST	MONDEO-2.0L DIESEL	AHCM(Auxiliary Heater Control Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.0L DIESEL	BCMii(Body Control Module)				V	V	V							V					V																																
BETA-TEST	MONDEO-2.0L DIESEL	CCMii(Cruise Control Module)				V	V	V	V						V					V																																
BETA-TEST	MONDEO-2.0L DIESEL	CMR(Camera Module Rear)				V	V	V												V																																
BETA-TEST	MONDEO-2.0L DIESEL	DDM(Driver's Door Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.0L DIESEL	DSM(Driver's Seat Module)				V	V	V							V					V																																
BETA-TEST	MONDEO-2.0L DIESEL	HCM(Headlamp Control Module)				V	V	V							V					V																																
BETA-TEST	MONDEO-2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)				V	V	V							V					V																																
BETA-TEST	MONDEO-2.0L DIESEL	IPC(Instrument Panel Control Module)				V	V	V							V					V																																
BETA-TEST	MONDEO-2.0L DIESEL	PAM(Parking Aid Module)				V	V	V							V					V																																
BETA-TEST	MONDEO-2.0L DIESEL	PBM(Parking Brake Control Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.0L DIESEL	PDM(Passenger's Door Module)				V	V	V							V					V																																
BETA-TEST	MONDEO-2.0L DIESEL	PSCM(Power Steering Control Module)				V	V	V							V					V																																
BETA-TEST	MONDEO-2.0L DIESEL	RCM(Restraint Control Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.0L DIESEL	RFA(Remote Function Actuator)				V	V	V							V					V																																
BETA-TEST	MONDEO-2.0L DIESEL	SASM(Steering Angle Sensor Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.0L DIESEL	SRM(Speech Recognition Module)				V	V								V					V																																
BETA-TEST	MONDEO-2.0L DIESEL	TCM(Transmission Control Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.0L DIESEL	TRM(Trailer Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.0L DIESEL	VDM(Vehicle Dynamic Module)				V	V	V							V					V																																
BETA-TEST	MONDEO-2.5L GASOLINE	SYSTEM SEARCH																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	PCM(PowerTrain Control Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	ABS(Anti-Lock Brake System)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	BCMii(Body Control Module)				V	V	V	V											V																																
BETA-TEST	MONDEO-2.5L GASOLINE	CCMii(Cruise Control Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	CMR(Camera Module Rear)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	DDM(Driver's Door Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	DSM(Driver's Seat Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	HCM(Headlamp Control Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	IPC(Instrument Panel Control Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	PAM(Parking Aid Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	PBM(Parking Brake Control Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	PDM(Passenger's Door Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	PSCM(Power Steering Control Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	RCM(Restraint Control Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	RFA(Remote Function Actuator)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	SASM(Steering Angle Sensor Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	SRM(Speech Recognition Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	TCM(Transmission Control Module)				V	V	V												V																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Incode calculator	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	ON-Demand Self test	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Remote Keyless Entry	ECU Information Display	Reset KAM	Relearn Vehicle Data	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	ABS Service Bleed	Longitudinal Acceleration Sensor	ACM Module Installation	Key On Engine Off Self Test apim	CEI Lock Configuration	BMS Reset	Factory Keyless Entry Code	Remote Keyless Entry Code	CCM Calibration	CCM Module Installation	HVAC Module Installation	RCM Module Installation	Reset KAM TCM	IVD Initialzation Sequence	ABS Module Installation	IC Installation-Test	IC Module Installation	Reset the Intake Air Throttle Valve Learned Values	Reset the Powertrain Control Module Learned Values	Stop-Start Activation	Camshaft Position Reference Adaption Learn	Brake Calliper	Drum Brake-Wheel Cylinder	Brake Hose	Brake Tubes	Brake Master Cylinder
BETA-TEST	MONDEO-2.5L GASOLINE	TRM(Trailer Module)				V	V	V												V																																
BETA-TEST	MONDEO-2.5L GASOLINE	VDM(Vehicle Dynamic Module)				V	V	V												V																																
BETA-TEST	MONDEO-3.0L Duratec-ST	SYSTEM SEARCH																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	PCM(PowerTrain Control Module)				V	V	V	V																																											
BETA-TEST	MONDEO-3.0L Duratec-ST	ABS(Anti-Lock Brake System)				V	V	V	V																		V																										
BETA-TEST	MONDEO-3.0L Duratec-ST	ACM(Audio Control Module)				V	V	V																																												
BETA-TEST	MONDEO-3.0L Duratec-ST	CDP(Compact Disc Player)				V	V	V																																												
BETA-TEST	MONDEO-3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)				V	V	V																																												
BETA-TEST	MONDEO-3.0L Duratec-ST	GDM(Generic Display Module)				V	V	V																																												
BETA-TEST	MONDEO-3.0L Duratec-ST	GEM(Generic Electronic Module)				V	V	V	V										V																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)				V	V	V	V																																												
BETA-TEST	MONDEO-3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)				V	V	V																																												
BETA-TEST	MONDEO-3.0L Duratec-ST	NAV(Navigation System)				V	V	V																																												
BETA-TEST	MONDEO-3.0L Duratec-ST	RCM(Restraint Control Module)				V	V	V																																												
BETA-TEST	MONDEO-3.0L Duratec-ST	RETM(Rear Entertainment Module)				V	V	V																																												
BETA-TEST	MONDEO-3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)				V	V	V																																												
BETA-TEST	MONDEO-3.0L Duratec-ST	SRM(Speech Recognition Module)				V	V	V																																												
BETA-TEST	F-150 5.4L	SYSTEM SEARCH																																																		
BETA-TEST	F-150 5.4L	PCM(PowerTrain Control Module)				V	V	V	V					V	V	V				V	V		V	V	V	V																										
BETA-TEST	F-150 5.4L	4X4(4x4 Control Module)				V	V	V	V						V																																					
BETA-TEST	F-150 5.4L	ABS(Anti-Lock Brake System)				V	V	V	V						V												V													V													
BETA-TEST	F-150 5.4L	DSM(Driver Seat Module)				V		V	V																																											
BETA-TEST	F-150 5.4L	EATC(Electronic Automatic Temperature Control)				V		V	V																																											
BETA-TEST	F-150 5.4L	IC(Instrument Cluster)				V	V	V	V						V																											V											
BETA-TEST	F-150 5.4L	PAM(Parking Aid Module)				V		V	V																																											
BETA-TEST	F-150 5.4L	RCM(Restraint Control Module)				V		V	V																																											
BETA-TEST	F-150 5.4L	VSM(Vehicle Security Module)				V		V	V																																											
BETA-TEST	F-150 5.4L	PATS(Passive Anti Theft System)				V	V													V																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	SYSTEM SEARCH																																																		
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PCM(PowerTrain Control Module)				V	V	V						V						V	V		V	V	V	V																										
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	ABS(Anti-Lock Brake System)				V	V	V	V						V												V																										
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	IC(Instrument Cluster)				V	V	V	V						V																											V											
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PAM(Parking Aid Module)				V		V	V																																											
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	RCM(Restraint Control Module)				V		V	V																																											
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	VSM(Vehicle Security Module)				V	V	V	V						V																																					
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																		
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																		
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
Incode Calculator	~2010.05	All model																																																		
ESCAPE	Up to 2004	SYSTEM SEARCH																																																		
ESCAPE	Up to 2004	PCM(PowerTrain Control Module)																																																		
ESCAPE	Up to 2004	Immobilizer																																																		
ESCAPE	Up to 2004	ABS(Anti-Lock Brake System)																																																		
ESCAPE	Up to 2004	RCM(Restraint Control Module)																																																		
ESCAPE	Up to 2004	GEM(Generic Electronic Module)																																																		
ESCAPE	From 2004	SYSTEM SEARCH																																																		
ESCAPE	From 2004	PCM(PowerTrain Control Module)																																																		
ESCAPE	From 2004	PATS(Passive anti theft system)																																																		
ESCAPE	From 2004	ABS(Anti-Lock Brake System)																																																		
ESCAPE	From 2004	ABS(Anti-Lock Brake System)																																																		
ESCAPE	From 2004	RCM(Restraint Control Module)																																																		
ESCAPE	From 2004	IC(Instrument Cluster)																																																		
ESCAPE	From 2004	GEM(Generic Electronic Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	SYSTEM SEARCH																																																	
EXPLORER	2011 MY	3.5L TiCVT	PCM(Powertrain Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2011 MY	3.5L TiCVT	ACM(Audio Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	BCM(Body Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	ATCM(All Terrain Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	C-CM(Cruise Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	CLM(Column Lock Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	DCSM(Driver-Dual Climate Contol Seat Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	DSM(Driver Seat Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	DSP(Digital Signal Processing Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	FCIM(Front Controls Interface Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	FCDIM(Front Control/Display Interface Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	FLM(Front Lighting Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	GPSM(Global Positioning System Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	HUD(Head Up Display)																																																	
EXPLORER	2011 MY	3.5L TiCVT	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER	2011 MY	3.5L TiCVT	IPC(Instrument Panel Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	LTM(Liftgate/Trunk Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	PAM(Parking Aid Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	PSCM(Power Steering Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	RCM(Restraint Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	RFA(Remote Function Actuator)																																																	
EXPLORER	2011 MY	3.5L TiCVT	RLCM-A(Rear Lighting Control Module A)																																																	
EXPLORER	2011 MY	3.5L TiCVT	SCCM(Streering Colume Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
EXPLORER	2011 MY	3.5L TiCVT	SOD-L(Side Obstacle Detection Control Module Left)																																																	
EXPLORER	2011 MY	3.5L TiCVT	SOD-R(Side Obstacle Detection Control Module Right)																																																	
EXPLORER	2011 MY	3.5L TiCVT	TPM(Tire Pressure Monitor)																																																	
EXPLORER	2010 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2010 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2010 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER	2010 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2010 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER	2010 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER	2010 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2010 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER	2010 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER	2010 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2009 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2009 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2009 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER	2009 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2009 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER	2009 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER	2009 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2009 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER	2009 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER	2009 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2008 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2008 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2008 MY	4.6L	TCM(Transmission Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
EXPLORER	2008 MY	4.6L	4X4(4x4 Control Module)																																																
EXPLORER	2008 MY	4.6L	ABS(Anti-Lock Brake System)																																																
EXPLORER	2008 MY	4.6L	ACM(Audio Control Module)																																																
EXPLORER	2008 MY	4.6L	DSM(Driver's Seat Module)																																																
EXPLORER	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																
EXPLORER	2008 MY	4.6L	GEM(Generic Electronic Module)																																																
EXPLORER	2008 MY	4.6L	IC(Instrument Cluster)																																																
EXPLORER	2008 MY	4.6L	OCSM(Occupant Classification System Module)																																																
EXPLORER	2008 MY	4.6L	PAM(Parking Aid Module)																																																
EXPLORER	2008 MY	4.6L	PRB(Power Running Board)																																																
EXPLORER	2008 MY	4.6L	RCM(Restraint Control Module)																																																
EXPLORER	2008 MY	4.6L	RETM(Rear Entertainment Module)																																																
EXPLORER	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
EXPLORER	2007 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER	2007 MY	4.6L	PCM(Powertrain Control Module)																																																
EXPLORER	2007 MY	4.6L	TCM(Transmission Control Module)																																																
EXPLORER	2007 MY	4.6L	4X4(4x4 Control Module)																																																
EXPLORER	2007 MY	4.6L	ABS(Anti-Lock Brake System)																																																
EXPLORER	2007 MY	4.6L	ACM(Audio Control Module)																																																
EXPLORER	2007 MY	4.6L	DSM(Driver's Seat Module)																																																
EXPLORER	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																
EXPLORER	2007 MY	4.6L	GEM(Generic Electronic Module)																																																
EXPLORER	2007 MY	4.6L	IC(Instrument Cluster)																																																
EXPLORER	2007 MY	4.6L	OCSM(Occupant Classification System Module)																																																
EXPLORER	2007 MY	4.6L	PAM(Parking Aid Module)																																																
EXPLORER	2007 MY	4.6L	PRB(Power Running Board)																																																
EXPLORER	2007 MY	4.6L	RCM(Restraint Control Module)																																																
EXPLORER	2007 MY	4.6L	RETM(Rear Entertainment Module)																																																
EXPLORER	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
EXPLORER	2006 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER	2006 MY	4.6L	PCM(Powertrain Control Module)																																																
EXPLORER	2006 MY	4.6L	TCM(Transmission Control Module)																																																
EXPLORER	2006 MY	4.6L	4X4(4x4 Control Module)																																																
EXPLORER	2006 MY	4.6L	ABS(Anti-Lock Brake System)																																																
EXPLORER	2006 MY	4.6L	ACM(Audio Control Module)																																																
EXPLORER	2006 MY	4.6L	DSM(Driver's Seat Module)																																																
EXPLORER	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																
EXPLORER	2006 MY	4.6L	GEM(Generic Electronic Module)																																																
EXPLORER	2006 MY	4.6L	IC(Instrument Cluster)																																																
EXPLORER	2006 MY	4.6L	OCSM(Occupant Classification System Module)																																																
EXPLORER	2006 MY	4.6L	PAM(Parking Aid Module)																																																
EXPLORER	2006 MY	4.6L	PRB(Power Running Board)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
EXPLORER	2006 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2006 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2000 MY	SYSTEM SEARCH																																																		
EXPLORER	2000 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	2000 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	2000 MY	RCM(Restraint Control Module)																																																		
EXPLORER	2000 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER	2000 MY	GEM(Generic Electronic Module)																																																		
EXPLORER	2000 MY	PAM(Parking Aid Module)																																																		
EXPLORER	1999 MY	SYSTEM SEARCH																																																		
EXPLORER	1999 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	1999 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	1999 MY	RCM(Restraint Control Module)																																																		
EXPLORER	1999 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER	1999 MY	PAM(Parking Aid Module)																																																		
EXPLORER	1998 MY	SYSTEM SEARCH																																																		
EXPLORER	1998 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	1998 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	1998 MY	RCM(Restraint Control Module)																																																		
EXPLORER	1998 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER	1997 MY	SYSTEM SEARCH																																																		
EXPLORER	1997 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	1997 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	1997 MY	RCM(Restraint Control Module)																																																		
EXPLORER	1997 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	RCM(Restraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
EXPLORER SPORT-TRAC	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
EXPLORER SPORT-TRAC	2007 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)		V	V	V	V	V																																											
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)							V	V																																										
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)									V	V																																							
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)											V	V	V	V	V	V	V	V	V	V	V																												
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)		V	V	V	V	V																																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	BCM(Body Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	GPSM(Global Positioning System Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)							V	V																																										
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)									V	V																																								
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
ECOSPORT	1.5L	DURATEC VCT	SYSTEM SEARCH																																																	
ECOSPORT	1.5L	DURATEC VCT	PCM(Powertrain Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	ABS(Anti-Lock Brake System)		V	V	V	V	V																																												
ECOSPORT	1.5L	DURATEC VCT	ACM(Audio Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	BCMii(Body Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	GPSM(Global Positioning System Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																	
ECOSPORT	1.5L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	PSCM(Power Steering Control Module)							V	V																																										
ECOSPORT	1.5L	DURATEC VCT	RCM(Restraint Control Module)									V	V																																								
ECOSPORT	1.5L	DURATEC VCT	RFA(Remote Function Actuator)																																																	
ECOSPORT	1.5L	DURATEC VCT	TCM(Transmission Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	SYSTEM SEARCH																																																	
FIESTA	1.25L	DURATEC 16V	PCM(PowerTrain Control Module)																						V																												
FIESTA	1.25L	DURATEC 16V	ABS(Anti-Lock Brake System)					V	V																	V	V	V	V	V	V	V	V	V	V	V	V															
FIESTA	1.25L	DURATEC 16V	ACM(Audio Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	APIM(Accessory Protocol Interface Module)																																																	
FIESTA	1.25L	DURATEC 16V	BCMii(Body Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	DDM(Driver's Door Module)																																																	
FIESTA	1.25L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.25L	DURATEC 16V	FDSM(Front Distance Sensing Module)																																																	
FIESTA	1.25L	DURATEC 16V	GPSM(Global Positioning System Module)																																																	
FIESTA	1.25L	DURATEC 16V	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.25L	DURATEC 16V	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	PDM(Passenger's Door Module)																																																	
FIESTA	1.25L	DURATEC 16V	PSCM(Power Steering Control Module)								V																											V	V	V													
FIESTA	1.25L	DURATEC 16V	RCM(Restraint Control Module)									V	V																												V												
FIESTA	1.25L	DURATEC 16V	RFA(Remote Function Actuator)																																																	
FIESTA	1.4L GASOLINE	SYSTEM SEARCH																																																		
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																								V										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)																																									V								
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)																																										V							
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																											V						
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)						V	V																V	V	V		V	V	V	V	V	V	V	V															
FIESTA	1.4L GASOLINE	APIM(Accessory Protocol Interface Module)																																																	
FIESTA	1.4L GASOLINE	PSCM(Power Steering Control Module)								V	V																												V	V												
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)																																											V						
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)										V																																							
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.4L GASOLINE	GEM(Generic Electronic Module)																																																	
FIESTA	1.4L GASOLINE	BCMii(Body Control Module)																																																	
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.4L GASOLINE	RFA(Remote Function Actuator)																																																	
FIESTA	1.4L GASOLINE	SRM(Speech Recognition Module)																																																	
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)																																																	
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)																																																	
FIESTA	1.4L GASOLINE	DDM(Driver's Door Module)																																																	
FIESTA	1.4L GASOLINE	FDSM(Front Distance Sensing Module)																																																	
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.4L GASOLINE	GPSM(Global Positioning System Module)																																																	
FIESTA	1.4L GASOLINE	PDM(Passenger's Door Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)													V																														V	V					
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																			V													
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																									V				V	V		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																										V						
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																			V	V												
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)																																											V					
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																																															V	V
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)											V	V		V			V	V	V	V	V																												
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)					V	V																	V	V	V		V	V	V	V	V	V	V	V															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)						V	V																												V	V													
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)											V						V				V																								V					
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)					V	V																	V	V	V		V	V	V	V	V	V	V	V															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)						V	V																												V	V													
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																
FIESTA	1.5L	TiVCT	SYSTEM SEARCH																																																
FIESTA	1.5L	TiVCT	PCM(PowerTrain Control Module)																						V																												
FIESTA	1.5L	TiVCT	ABS(Anti-Lock Brake System)					V	V																	V	V	V		V	V	V	V	V	V	V	V															
FIESTA	1.5L	TiVCT	ACM(Audio Control Module)																																																
FIESTA	1.5L	TiVCT	BCMii(Body Control Module)																																																
FIESTA	1.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																																																
FIESTA	1.5L	TiVCT	IPC(Instrument Panel Control Module)																																																
FIESTA	1.5L	TiVCT	PSCM(Power Steering Control Module)						V	V																												V	V													
FIESTA	1.5L	TiVCT	RCM(Retraint Control Module)																																																
FIESTA	1.5L	TiVCT	RFA(Remote Function Actuator)																																																
FIESTA	1.5L	TiVCT	SRM(Speech Recognition Module)																																																
FIESTA	1.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																																																
FIESTA	1.5L	TiVCT	TCM(Transmission Control Module)																																																
FIESTA	1.6L GASOLINE	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																								V									
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)																																									V								
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)																																										V							
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																											V				V	V	
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)						V	V																	V	V	V		V	V	V	V	V	V	V	V														
FIESTA	1.6L GASOLINE	PSCM(Power Steering Control Module)								V	V																												V	V												
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)																																												V					
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)										V																																							
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)																																												V					
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)																																																	
FIESTA	1.6L GASOLINE	BCMii(Body Control Module)																																																	
FIESTA	1.6L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)																																																	
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)																																																	
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)																																																	
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)																																												V					
FIESTA	1.6L ZETEC ROCAM	SYSTEM SEARCH																																																	
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)																																																	
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)																																																	
FIESTA	1.6L ZETEC ROCAM	ABS(Anti-Lock Brake System)																																											V				V	V	
FIESTA	1.6L ZETEC ROCAM	IC(Instrument Cluster)																																																	
FIESTA	1.6L ZETEC ROCAM	RCM(Restraint Control Module)																																																	
FIESTA	1.6L ZETEC ROCAM	RKE(Remote Keyless Entry)																																																	
FIESTA	1.6L ZETEC ROCAM	TCM(Transmission Control Module)																																																	
FIESTA	1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																																	
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																	
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																	
FIESTA	1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																																																	
FIESTA	1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																																											V				V	V	
FIESTA	2.0L GASOLINE	SYSTEM SEARCH																																																	
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																								V									
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																											V				V	V	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)						V	V																	V	V	V		V	V	V	V	V	V	V	V															
FIESTA	2.0L GASOLINE	ACM(Audio Control Module)																																												V						
FIESTA	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FIESTA	2.0L GASOLINE	GEM(Generic Electronic Module)																																												V						
FIESTA	2.0L GASOLINE	IC(Instrument Cluster)																																												V						
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)																																																		
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)																																																		
FIESTA	2.0L GASOLINE	RCM(Restraint Control Module)																																																		
FIESTA	2.0L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	V	V
FIGO	1.4L DIESEL	SYSTEM SEARCH																																																		
FIGO	1.4L DIESEL	PCM(Powertrain Control Module)																																																		
FIGO	1.4L DIESEL	ABS(Anti-Lock Brake System)																																															V	V		
FIGO	1.4L DIESEL	IC(Instrument Cluster)																																																		
FIGO	1.4L DIESEL	RCM(Restraint Control Module)																																																		
FIGO	1.6L	DURATEC 16V	SYSTEM SEARCH																																																	
FIGO	1.6L	DURATEC 16V	PCM(Powertrain Control Module)																																																	
FIGO	1.6L	DURATEC 16V	ABS(Anti-Lock Brake System)																																														V	V		
FIGO	1.6L	DURATEC 16V	GEM(Generic Electronic Module)																																																	
FIGO	1.6L	DURATEC 16V	IC(Instrument Cluster)																																																	
FIGO	1.6L	DURATEC 16V	RCM(Restraint Control Module)																																																	
FIGO	1.6L	DURATEC 16V	TCM(Transmission Control Module)																																								V									
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM(Front Distance Sensing Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																
FOCUS	1.4L	DURATEC 16V	SYSTEM SEARCH																																																
FOCUS	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																																																
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																
FOCUS	1.4L	DURATEC 16V	ACM(Audio Control Module)																																																
FOCUS	1.4L	DURATEC 16V	CDP(Compact Disc Player)																																																
FOCUS	1.4L	DURATEC 16V	D_DCU(Driver Door Control Unit)																																																
FOCUS	1.4L	DURATEC 16V	GDM(Generic Display Module)																																																
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																																																
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																																										V						
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)																																																
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)																																																
FOCUS	1.4L	DURATEC 16V	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	1.4L	DURATEC 16V	FFH(Fuel Fired Coolant Heating Module)																																																
FOCUS	1.4L	DURATEC 16V	IC(Instrument Cluster)																																																
FOCUS	1.4L	DURATEC 16V	NAV(Navigation System)																																																
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)																																																
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)																																																
FOCUS	1.4L	DURATEC 16V	PDM(Passenger's Door Module)																																										V						
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)																																																
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)																																																
FOCUS	1.4L	DURATEC 16V	RKE(Remote Keyless Entry)																																																
FOCUS	1.4L	DURATEC 16V	CSM(Central Security Module)																																																
FOCUS	1.4L	DURATEC 16V	HEC(Hybrid Electrical Cluster)																																																
FOCUS	1.4L	DURATEC 16V	MC(Message Center)																																																
FOCUS	1.4L	DURATEC 16V	RETM(Rear Entertainment Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)											V	V		V	V			V																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TCM(Transmission Control Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)		V	V	V	V	V																											V																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body control module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	CCMii(Cruise Control Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	DDM(Driver's Door Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	DDM(Driver's Door Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FCIM(Front Controls Interface Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FDSM(Front Distance Sensing Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	GPSM(Global Positioning System Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	HCM(Headlamp Control Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	HVAC(Heating Ventilation Air Conditioning)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	IPM-A(Image Processing Module A)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	IPC(Instrument Panel Control Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PAM(Parking Aid Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PDM(Passenger's Door Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PSCM(Power Steering Control Module)								V																																								
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	RCM(Restraint Control Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	RFA(Remote Function Actuator)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SASM(Steering Angle Sensor Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SOD-L(Side Obstacle Detection Control Module Left)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SOD-R(Side Obstacle Detection Control Module Right)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	TRM(Trailer Module)																																																
FOCUS	1.6L GASOLINE	ZETEC SE	SYSTEM SEARCH																																																
FOCUS	1.6L GASOLINE	ZETEC SE	PCM(PowerTrain Control Module)																																																
FOCUS	1.6L GASOLINE	ZETEC SE	ABS(Anti-Lock Brake System)																																									V							
FOCUS	1.6L GASOLINE	ZETEC SE	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	1.6L GASOLINE	ZETEC SE	GEM(Generic Electronic Module)																																																
FOCUS	1.6L GASOLINE	ZETEC SE	RCM(Restraint Control Module)																																																
FOCUS	1.6L GASOLINE	ZETEC SE	MC(Message Center)																																																
FOCUS	1.6L GASOLINE	DURATEC	SYSTEM SEARCH																																																
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)																																																
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)																																																
FOCUS	1.6L GASOLINE	DURATEC	ACM(Audio Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	CDP(Compact Disc Player)																																																
FOCUS	1.6L GASOLINE	DURATEC	D_DCU(Driver Door Control Unit)																																																
FOCUS	1.6L GASOLINE	DURATEC	GDM(Generic Display Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)																																										V						
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	1.6L GASOLINE	DURATEC	FFH(Fuel Fired Coolant Heating Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FOCUS	1.6L GASOLINE	DURATEC	IC(Instrument Cluster)																																																
FOCUS	1.6L GASOLINE	DURATEC	NAV(Navigation System)																																																
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	PDM(Passenger's Door Module)																																											V					
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	RKE(Remote Keyless Entry)																																																
FOCUS	1.6L GASOLINE	DURATEC	RL_DCU(Rear Left Door Control Unit)																																																
FOCUS	1.6L GASOLINE	DURATEC	RR_DCU(Rear Right Door Control Unit)																																																
FOCUS	1.6L GASOLINE	DURATEC	CSM(Central Security Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	HEC(Hybrid Electrical Cluster)																																																
FOCUS	1.6L GASOLINE	DURATEC	MC(Message Center)																																																
FOCUS	1.6L GASOLINE	DURATEC	PATS(Passive Anti Theft System)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SYSTEM SEARCH																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TCM(Transmission Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)				V	V	V																				V	V	V	V	V	V	V	V																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	APIM(Accessory Protocol Interface Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	BCMii(Body Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	CCMii(Cruise Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DDM(Driver's Door Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DSP(Digital Signal Processing Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCIM(Front Controls Interface Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FDSM(Front Distance Sensing Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HCM(Headlamp Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-A(Image Processing Module A)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-B(Image Processing Module B)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPC(Instrument Panel Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)																																											V					
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PSCM(Power Steering Control Module)								V																																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RFA(Remote Function Actuator)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SASM(Steering Angle Sensor Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SRM(Speech Recognition Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TRM(Trailer Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PATS(Passive Anti Theft System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)												V		V	V			V			V	V																												
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)				V	V	V																																											
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GDM(Generic Display Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	NAV(Navigation System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Condtioning)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																																															V	V
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)												V		V	V	V		V			V	V																											
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)		V	V	V	V	V																												V															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Condtioning)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)								V																																								
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																										V						
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CMR(Camera Module Rear)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CDP(Compact Disc Player)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																										V						
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPB(Electronic Parking Brake)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPS(Electronic Power Steering)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GDM(Generic Display Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)																																										V						
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HCM(Headlamp Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	IC(Instrument Cluster)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	NAV(Navigation System)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PDM(Passenger's Door Module)																																										V						
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CSM(Central Security Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	MC(Message Center)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SYSTEM SEARCH																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	TCM(Transmission Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																										V						
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ACM(Audio Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CMR(Camera Module Rear)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CDP(Compact Disc Player)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CSM(Central Security Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																										V						
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPB(Electronic Parking Brake)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPS(Electronic Power Steering)																																										V						
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GDM(Generic Display Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)																																											V						
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HCM(Headlamp Control Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	IC(Instrument Cluster)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)																																											V						
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	NAV(Navigation System)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PAM(Parking Aid Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PDM(Passenger's Door Module)																																											V						
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SRM(Speech Recognition Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SYSTEM SEARCH																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TCM(Transmission Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)				V	V	V																				V	V	V	V	V	V	V	V																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	APIM(Accessory Protocol Interface Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	BCMii(Body Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	CCMii(Cruise Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DDM(Driver's Door Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DSP(Digital Signal Processing Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCIM(Front Controls Interface Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FDSM(Front Distance Sensing Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HCM(Headlamp Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-A(Image Processing Module A)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-B(Image Processing Module B)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPC(Instrument Panel Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)																																											V						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PSCM(Power Steering Control Module)								V																																									
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RFA(Remote Function Actuator)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SASM(Steering Angle Sensor Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SRM(Speech Recognition Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TRM(Trailer Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PATS(Passive Anti Theft System)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	SYSTEM SEARCH																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PCM(PowerTrain Control Module)										V																																						
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	TCM(Transmission Control Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ACM(Audio Control Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ABS(Anti-Lock Brake System)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CDP(Compact Disc Player)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CMR(Camera Module Rear)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	D_DCU(Driver Door Control Unit)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	EPS(Electronic Power Steering)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FACM(Fuel Additive Control Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FFH(Fuel Fired Coolant Heating Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	GEM(Generic Electronic Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	HCM(Headlamp Control Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	IC(Instrument Cluster)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PDM(Passenger's Door Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PAM(Parking Aid Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RCM(Restraint Control Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RETM(Rear Entertainment Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RKE(Remote Keyless Entry)																																																
FOCUS	2.5L GASOLINE	SYSTEM SEARCH																																																		
FOCUS	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																		
FOCUS	2.5L GASOLINE	TCM(Transmission Control Module)																																																		
FOCUS	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																												V						
FOCUS	2.5L GASOLINE	EPS(Electronic Power Steering)																																												V						
FOCUS	2.5L GASOLINE	RCM(Restraint Control Module)																																												V						
FOCUS	2.5L GASOLINE	GEM(Generic Electronic Module)																																												V						
FOCUS	2.5L GASOLINE	IC(Instrument Cluster)																																																		
FOCUS	2.5L GASOLINE	DDM(Driver's Door Module)																																												V						
FOCUS	2.5L GASOLINE	PDM(Passenger's Door Module)																																												V						
FOCUS	2.5L GASOLINE	MC(Message Center)																																												V						
FOCUS	2.5L GASOLINE	ACM(Audio Control Module)																																												V						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FOCUS C-MAX	1.6L DIESEL	SYSTEM SEARCH																																																		
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)													V		V	V			V			V	V																											
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																		
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)					V	V	V																																											
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	CDP(Compact Disc Player)																																																		
FOCUS C-MAX	1.6L DIESEL	CMR(Camera Module Rear)																																																		
FOCUS C-MAX	1.6L DIESEL	D_DCU(Driver Door Control Unit)																																																		
FOCUS C-MAX	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS C-MAX	1.6L DIESEL	EPS(Electronic Power Steering)																																																		
FOCUS C-MAX	1.6L DIESEL	FACM(Fuel Additive Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS C-MAX	1.6L DIESEL	GEM(Generic Electronic Module)																																																		
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	IC(Instrument Cluster)																																																		
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)																																																		
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)																																																		
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	RETM(Rear Entertainment Module)																																																		
FOCUS C-MAX	1.6L DIESEL	RKE(Remote Keyless Entry)																																																		
FOCUS C-MAX	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	BCMii(Body Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	DDM(Driver's Door Module)																																																		
FOCUS C-MAX	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)																																																		
FOCUS C-MAX	1.6L DIESEL	HVAC(Heating Ventilation Air Condtioning)																																																		
FOCUS C-MAX	1.6L DIESEL	IPM-A(Image Processing Module A)																																																		
FOCUS C-MAX	1.6L DIESEL	IPM-B(Image Processing Module B)																																																		
FOCUS C-MAX	1.6L DIESEL	IPC(Instrument Panel Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	PSCM(Power Steering Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	RFA(Remote Function Actuator)																																																		
FOCUS C-MAX	1.6L DIESEL	RGTM(Rear Gate/Trunk Module)																																																		
FOCUS C-MAX	1.6L DIESEL	SASM(Steering Angle Sensor Module)																																																		
FOCUS C-MAX	1.6L DIESEL	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	1.6L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																		
FOCUS C-MAX	1.6L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																		
FOCUS C-MAX	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																																V	V

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FOCUS C-MAX	1.6L GASOLINE	SYSTEM SEARCH																																																		
FOCUS C-MAX	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FOCUS C-MAX	1.6L GASOLINE	ACM(Audio Control Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	CDP(Compact Disc Player)																																																		
FOCUS C-MAX	1.6L GASOLINE	CMR(Camera Module Rear)																																																		
FOCUS C-MAX	1.6L GASOLINE	D_DCU(Driver Door Control Unit)																																																		
FOCUS C-MAX	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS C-MAX	1.6L GASOLINE	EPS(Electronic Power Steering)																																																		
FOCUS C-MAX	1.6L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	GEM(Generic Electronic Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	IC(Instrument Cluster)																																																		
FOCUS C-MAX	1.6L GASOLINE	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	PDM(Passenger's Door Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	RETM(Rear Entertainment Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	RKE(Remote Keyless Entry)																																																		
FOCUS C-MAX	1.6L GASOLINE	GDM(Generic Display Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	NAV(Navigation System)																																																		
FOCUS C-MAX	1.6L GASOLINE	RL_DCU(Rear Left Door Control Unit)																																																		
FOCUS C-MAX	1.6L GASOLINE	RR_DCU(Rear Right Door Control Unit)																																																		
FOCUS C-MAX	1.6L GASOLINE	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	TCM(Transmission Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	SYSTEM SEARCH																																																		
FOCUS C-MAX	1.8L GASOLINE	PCM(PowerTrain Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	ABS(Anti-Lock Brake System)																																												V						
FOCUS C-MAX	1.8L GASOLINE	ACM(Audio Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	CMR(Camera Module Rear)																																																		
FOCUS C-MAX	1.8L GASOLINE	CDP(Compact Disc Player)																																																		
FOCUS C-MAX	1.8L GASOLINE	D_DCU(Driver Door Control Unit)																																												V						
FOCUS C-MAX	1.8L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS C-MAX	1.8L GASOLINE	EPB(Electronic Parking Brake)																																																		
FOCUS C-MAX	1.8L GASOLINE	EPS(Electronic Power Steering)																																																		
FOCUS C-MAX	1.8L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	GDM(Generic Display Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	GEM(Generic Electronic Module)																																												V						
FOCUS C-MAX	1.8L GASOLINE	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	IC(Instrument Cluster)																																																		
FOCUS C-MAX	1.8L GASOLINE	NAV(Navigation System)																																																		
FOCUS C-MAX	1.8L GASOLINE	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	PDM(Passenger's Door Module)																																												V						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FOCUS C-MAX	1.8L GASOLINE	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	RETM(Rear Entertainment Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	RKE(Remote Keyless Entry)																																																		
FOCUS C-MAX	1.8L GASOLINE	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SYSTEM SEARCH																																																		
FOCUS C-MAX	2.0L DIESEL	PCM(PowerTrain Control Module)												V	V		V	V			V	V																															
FOCUS C-MAX	2.0L DIESEL	ABS(Anti-Lock Brake System)					V	V	V																																												
FOCUS C-MAX	2.0L DIESEL	ACM(Audio Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	BCMii(Body Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	DDM(Driver's Door Module)																																																		
FOCUS C-MAX	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																																																		
FOCUS C-MAX	2.0L DIESEL	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
FOCUS C-MAX	2.0L DIESEL	IPM-A(Image Processing Module A)																																																		
FOCUS C-MAX	2.0L DIESEL	IPM-B(Image Processing Module B)																																																		
FOCUS C-MAX	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	2.0L DIESEL	PDM(Passenger's Door Module)																																																		
FOCUS C-MAX	2.0L DIESEL	PSCM(Power Steering Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	RFA(Remote Function Actuator)																																																		
FOCUS C-MAX	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																		
FOCUS C-MAX	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																		
FOCUS C-MAX	2.0L GASOLINE	SYSTEM SEARCH																																																		
FOCUS C-MAX	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																												V						
FOCUS C-MAX	2.0L GASOLINE	ACM(Audio Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	CDP(Compact Disc Player)																																																		
FOCUS C-MAX	2.0L GASOLINE	CMR(Camera Module Rear)																																																		
FOCUS C-MAX	2.0L GASOLINE	D_DCU(Driver Door Control Unit)																																												V						
FOCUS C-MAX	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS C-MAX	2.0L GASOLINE	EPB(Electronic Parking Brake)																																																		
FOCUS C-MAX	2.0L GASOLINE	EPS(Electronic Power Steering)																																																		
FOCUS C-MAX	2.0L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	GDM(Generic Display Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	GEM(Generic Electronic Module)																																												V						
FOCUS C-MAX	2.0L GASOLINE	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	IC(Instrument Cluster)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
FOCUS C-MAX	2.0L GASOLINE	NAV(Navigation System)																																																	
FOCUS C-MAX	2.0L GASOLINE	PAM(Parking Aid Module)																																																	
FOCUS C-MAX	2.0L GASOLINE	PDM(Passenger's Door Module)																																												V					
FOCUS C-MAX	2.0L GASOLINE	RCM(Restraint Control Module)																																																	
FOCUS C-MAX	2.0L GASOLINE	RETM(Rear Entertainment Module)																																																	
FOCUS C-MAX	2.0L GASOLINE	RKE(Remote Keyless Entry)																																																	
FOCUS C-MAX	2.0L GASOLINE	SRM(Speech Recognition Module)																																																	
FUSION	1.4L DIESEL	SYSTEM SEARCH																																																	
FUSION	1.4L DIESEL	PCM(PowerTrain Control Module)																																																	
FUSION	1.4L DIESEL	TCM(Transmission Control Module)																																																	
FUSION	1.4L DIESEL	ABS(Anti-Lock Brake System)																																										V				V	V		
FUSION	1.4L DIESEL	IC(Instrument Cluster)																																											V						
FUSION	1.4L DIESEL	ACM(Audio Control Module)																																																	
FUSION	1.4L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
FUSION	1.4L DIESEL	GEM(Generic Electronic Module)																																																	
FUSION	1.4L DIESEL	SRM(Speech Recognition Module)																																																	
FUSION	1.4L DIESEL	RCM(Restraint Control Module)																																																	
FUSION	1.4L DIESEL	PATS(Passive Anti Theft System)-BETA																																																V	V
FUSION	1.6L DIESEL	SYSTEM SEARCH																																																	
FUSION	1.6L DIESEL	PCM(PowerTrain Control Module)																																																	
FUSION	1.6L DIESEL	TCM(Transmission Control Module)																																																	
FUSION	1.6L DIESEL	ABS(Anti-Lock Brake System)																																										V				V	V		
FUSION	1.6L DIESEL	IC(Instrument Cluster)																																											V						
FUSION	1.6L DIESEL	ACM(Audio Control Module)																																																	
FUSION	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
FUSION	1.6L DIESEL	GEM(Generic Electronic Module)																																																	
FUSION	1.6L DIESEL	SRM(Speech Recognition Module)																																																	
FUSION	1.6L DIESEL	RCM(Restraint Control Module)																																																	
FUSION	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																																V	V
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)					V																	V	V			V	V	V	V	V	V	V												V		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)												V		V	V			V			V																												
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)					V																		V	V			V	V	V	V	V	V	V													V		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)											V	V		V	V			V	V		V																											
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)					V																	V	V			V	V	V	V	V	V	V														V		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)					V																	V	V			V	V	V	V	V	V	V														V		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)											V			V			V	V	V	V																							V						
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)					V																		V	V			V	V	V	V	V	V	V														V			
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)											V	V		V			V	V	V	V																													
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TCM(Transmission Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)					V																		V	V			V	V	V	V	V	V	V														V		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CDP(Compact Disc Player)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CMR(Camera Module Rear)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DABM(Digital Audio Broadcast Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver's Seat Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	NAV(Navigation System)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PBM(Parking Brake Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module - Left)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module - Right)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																									V							
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																																																	
F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																																																	
F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																																																	
F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																																										V							
F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																																																	
F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																																																	
F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																																																	
F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																																																	
F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																																																	
F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																																																	
F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																																																	
F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																																																	
F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																																																	
F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																																																	
F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																																																	
F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																																																	
F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																																																	
F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																																																	
F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																																																	
F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																																																	
F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																																																	
F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																																																	
F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																																									V						
F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																																															
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																																															
F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																																															
F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																																															
F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																																															
F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																																															
F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																																															
F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																															
F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																																															
F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																																															
F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																																															
F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																																															
F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																																															
F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																																															
F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																																															
F150	4.6L(BETA)	3V	SYSTEM SEARCH																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																																																
F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																																										V						
F150	4.6L(BETA)	3V	ACM(Audio Control Module)																																																
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																																																
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																																																
F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																																																
F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																																																
F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																																																
F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																																																
F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																																																
F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																																																
F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																																																
F150	4.6L(BETA)	3V	IC(Instrument Cluster)																																																
F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																																																
F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																																																
F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																																																
F150	4.6L(BETA)	3V	PRB(Power Running Board)																																																
F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																																																
F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																																																
F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																																																
F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																																																
F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																																																
F150	5.0L	TiVCT	SYSTEM SEARCH																																																
F150	5.0L	TiVCT	PCM(Powertrain Control Module)																																																
F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																																										V						
F150	5.0L	TiVCT	ACM(Audio Control Module)																																																
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																																																
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																																																
F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																																																
F150	5.0L	TiVCT	DSM(Driver's Seat Module)																																																
F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																																																
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																
F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																																																
F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																																																
F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																																																
F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																																																
F150	5.0L	TiVCT	IC(Instrument Cluster)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																																																
F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																																																
F150	5.0L	TiVCT	PAM(Parking Aid Module)																																																
F150	5.0L	TiVCT	PAM(Parking Aid Module)																																																
F150	5.0L	TiVCT	PRB(Power Running Board)																																																
F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																																																
F150	5.0L	TiVCT	RCM(Restraint Control Module)																																																
F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																																																
F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																																																
F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																																																
F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																																																
F150	5.0L	TiVCT	TCM(Transmission Control Module)																																																
F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																																																
F150	5.4L	3V	2009 ~	SYSTEM SEARCH																																																
F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																																																
F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																																									V							
F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																																																
F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																																																
F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																																																
F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																																																
F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																																																
F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																																																
F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																																																
F150	5.4L	3V	2009 ~	GEMS/JB(Generic Electronic Module/Smart Junction Box)																																																
F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																																																
F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																																																
F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																																																
F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																																																
F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																																																
F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																																																
F150	5.4L	3V	2009 ~	PRB(Power Running Board)																																																
F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																																																
F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																																																
F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																																																
F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																																																
F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																																																
F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																																																
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																																															
F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																																															
F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																																															
F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																																															
F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																															
F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																																															
F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																																															
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																																															
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																																															
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																																															
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																																															
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																																															
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																																															
F150	6.2L(BETA)	2V	SYSTEM SEARCH																																															
F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																																															
F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																																									V						
F150	6.2L(BETA)	2V	ACM(Audio Control Module)																																															
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																																															
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																																															
F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																																															
F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																																															
F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																																															
F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																																															
F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																															
F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																																															
F150	6.2L(BETA)	2V	IC(Instrument Cluster)																																															
F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																																															
F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																																															
F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																																															
F150	6.2L(BETA)	2V	PRB(Power Running Board)																																															
F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																																															
F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																																															
F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																																															
F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																																															
F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																																															
F150	Other	2004 ~ 2008	SYSTEM SEARCH																																															
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																																															
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																																															
F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																																															
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																																															
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																																															
F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																																																	
F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																																																	
F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	Other	2004 ~ 2008	IC(Instrument Cluster)																																																	
F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																																																	
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																																																	
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																																																	
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																																																	
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																																																	
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																																																	
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																																																	
F250	7.3L	SYSTEM SEARCH																																																		
F250	7.3L	PCM(PowerTrain Control Module)																																																		
F250	7.3L	ABS(Anti-Lock Brake System)																																																		
F250	7.3L	ECS(Electronic Crash Sensor)																																																		
F250	7.3L	GEM(Generic Electronic Module)																																																		
F250	6.2L	SYSTEM SEARCH																																																		
F250	6.2L	PCM(Powertrain Control Module)																																																		
F250	6.2L	ABS(Anti-Lock Brake System)																																																		
F250	6.2L	ACM(Audio Control Module)																																																		
F250	6.2L	APIM(Accessory Protocol Interface Module)																																																		
F250	6.2L	BCMii(Body Control Module)																																																		
F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																																																		
F250	6.2L	DSM(Driver Seat Module)																																																		
F250	6.2L	GPSM(Global Positioning System Module)																																																		
F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																																																		
F250	6.2L	IPC(Instrument Panel Control Module)																																																		
F250	6.2L	PAM(Parking Aid Module)																																																		
F250	6.2L	RCM(Restraint Control Module)																																																		
F250	6.2L	SCCM(Streering Colume Control Module)																																																		
F250	6.2L	TBC(Trailer Brake Control Module)																																																		
F250	6.2L	TCCM(Transfer Case Control Module)																																																		
F250	6.2L	TPM(Tire Pressure Monitor)																																																		
F250	6.0L Diesel	SYSTEM SEARCH																																																		
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																		
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																		
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																		
F250	6.0L Diesel	ABS(Anti-Lock Brake System)																																																		
F250	6.0L Diesel	GEM(Generic Electronic Module)																																																		
F250	6.0L Diesel	HEC(Hybrid Electrical Cluster)																																																		
F250	6.0L Diesel	OTC(Overhead Trip Computer)																																																		
F250	6.0L Diesel	PAM(Parking Aid Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
F250	6.0L Diesel	PATS(Passive Anti Theft System)																																																		
F250	6.0L Diesel	RCM(Restraint Control Module)																																																		
F250	6.0L Diesel	TCM(Transmission Control Module)																																																		
F250	6.0L Diesel	TCM(Transmission Control Module)																																																		
F250	6.0L Diesel	TCM(Transmission Control Module)																																																		
F250	6.0L Diesel	VSM(Vehicle Security Module)																																																		
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																																																
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																	
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																	
KA	KA	SYSTEM SEARCH																																																		
KA	KA	PCM(PowerTrain Control Module)																																																		
KA	KA	ABS(Anti-Lock Brake System)																																																		
KA	KA	RCM(Restraint Control Module)																																																		
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
KUGA	2.0L DIESEL	SYSTEM SEARCH																																																		
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)												V																																	V				
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)												V	V		V	V			V	V		V																												
KUGA	2.0L DIESEL	TCM(Transmission Control Module)																																																		
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																		
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																		
KUGA	2.0L DIESEL	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
KUGA	2.0L DIESEL	ACM(Audio Control Module)																																																		
KUGA	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
KUGA	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																																																		
KUGA	2.0L DIESEL	AWD(All Wheel Drive Module)																																																		
KUGA	2.0L DIESEL	BCMii(Body Control Module)																																																		
KUGA	2.0L DIESEL	CCMii(Cruise Control Module)																																																		
KUGA	2.0L DIESEL	CMR(Camera Module Rear)																																																		
KUGA	2.0L DIESEL	D_DCU(Driver Door Control Unit)																																																		
KUGA	2.0L DIESEL	DDM(Driver's Door Module)																																																		
KUGA	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																		
KUGA	2.0L DIESEL	EPS(Electronic Power Steering)																																																		
KUGA	2.0L DIESEL	FDSM(Front Distance Sensing Module)																																																		
KUGA	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																																																		
KUGA	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																		
KUGA	2.0L DIESEL	GEM(Generic Electronic Module)																																																		
KUGA	2.0L DIESEL	GPSM(Global Positioning System Module)																																																		
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)																																																		
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)																																																		
KUGA	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
KUGA	2.0L DIESEL	IPM-A(Image Processing Module A)																																																		
KUGA	2.0L DIESEL	IPM-B(Image Processing Module B)																																																		
KUGA	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																		
KUGA	2.0L DIESEL	IC(Instrument Cluster)																																																		
KUGA	2.0L DIESEL	PAM(Parking Aid Module)																																																		
KUGA	2.0L DIESEL	PAM(Parking Aid Module)																																																		
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)																																																		
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)																																																		
KUGA	2.0L DIESEL	PSCM(Power Steering Control Module)																																																		
KUGA	2.0L DIESEL	RCM(Restraint Control Module)																																																		
KUGA	2.0L DIESEL	RCM(Restraint Control Module)																																																		
KUGA	2.0L DIESEL	RFA(Remote Function Actuator)																																																		
KUGA	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																		
KUGA	2.0L DIESEL	RETM(Rear Entertainment Module)																																																		
KUGA	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																		
KUGA	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																		
KUGA	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																		
KUGA	2.0L DIESEL	SRM(Speech Recognition Module)																																																		
KUGA	2.0L DIESEL	TRM(Trailer Module)																																																		
KUGA	2.5L GASOLINE	SYSTEM SEARCH																																																		
KUGA	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																		
KUGA	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																		
KUGA	2.5L GASOLINE	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
KUGA	2.5L GASOLINE	AWD(All Wheel Drive Module)																																																	
KUGA	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
KUGA	2.5L GASOLINE	D_DCU(Driver Door Control Unit)																																																	
KUGA	2.5L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
KUGA	2.5L GASOLINE	EPS(Electronic Power Steering)																																																	
KUGA	2.5L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																	
KUGA	2.5L GASOLINE	GEM(Generic Electronic Module)																																																	
KUGA	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
KUGA	2.5L GASOLINE	IC(Instrument Cluster)																																																	
KUGA	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
KUGA	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
KUGA	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
KUGA	2.5L GASOLINE	RETM(Rear Entertainment Module)																																																	
KUGA	2.5L GASOLINE	RKE(Remote Keyless Entry)																																																	
KUGA	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
KUGA	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)				V																	V	V			V	V	V	V	V	V	V															V		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)										V	V		V	V	V		V			V																						V						
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)																																									V						
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	CCMii(Cruise Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DCDC(DC to DC Convertal Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DDM(Driver's Door Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSM(Driver Seat Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSP(Digital Signal Processing Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCIM(Front Controls Interface Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FDSM(Front Distance Sensing Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCDIM(Front Control/Display Interface Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GPSM(Global Positioning System Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GWM(Gateway Module A)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HCM(Headlamp Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HSWM(Heated Steering Wheel Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HUD(Head Up Display)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPC(Instrument Panel Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PAM(Parking Aid Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PDM(Passenger's Door Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PSCM(Power Steering Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RACM(Rear Audio Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RCM(Restraint Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RGTM(Rear Gate/Trunk Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RTM(Radio Transceiver Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCCM(Streering Colume Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-E(Seat Control Module E)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-G(Seat Control Module G)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-H(Seat Control Module H)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SOD-L(Side Obstacle Detection Control Module Left)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SOD-R(Side Obstacle Detection Control Module Right)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TRM(Trailer Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)										V	V		V	V	V		V			V																					V					
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																							V						
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DCDC(DC to DC Convertal Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver Seat Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSP(Digital Signal Processing Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GWM(Gateway Module A)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HSWM(Heated Steering Wheel Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HUD(Head Up Display)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RACM(Rear Audio Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RTM(Radio Transceiver Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCCM(Streering Colume Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-E(Seat Control Module E)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-G(Seat Control Module G)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-H(Seat Control Module H)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)											V		V	V			V			V																										
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)				V																		V	V		V	V	V	V	V	V	V													V		
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)				V																	V	V		V	V	V	V	V	V	V													V				
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2012 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2012 MY	2.0L DIESEL	PCM(PowerTrain Control Module)											V	V		V	V			V	V																															
MONDEO	2012 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)					V																		V	V			V	V	V	V	V	V	V															V		
MONDEO	2012 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	BCMii(Body Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2012 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2012 MY	2.0L DIESEL	IPM-A(Image Processing Module A)																																																	
MONDEO	2012 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																	
MONDEO	2012 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
MONDEO	2012 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																	
MONDEO	2012 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																	
MONDEO	2012 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	TRM(Trailer Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)											V		V	V			V			V																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)				V																		V	V			V	V	V	V	V	V	V															V		
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)				V																	V	V			V	V	V	V	V	V	V													V			
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																															
MONDEO	2011 MY	2.0L DIESEL	SYSTEM SEARCH																																																
MONDEO	2011 MY	2.0L DIESEL	PCM(PowerTrain Control Module)											V	V		V	V			V	V																														
MONDEO	2011 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)					V																		V	V			V	V	V	V	V	V	V														V		
MONDEO	2011 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	BCMii(Body Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																
MONDEO	2011 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	2.0L DIESEL	IPM-A(Image Processing Module A)																																																
MONDEO	2011 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2011 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2011 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2011 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2011 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																
MONDEO	2011 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																
MONDEO	2011 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	TRM(Trailer Module)																																																
MONDEO	2011 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2011 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)					V																		V																										
MONDEO	2011 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2011 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2011 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2011 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2011 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2011 MY	2.5L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2011 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2011 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2011 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2011 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2011 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2010 MY	2.0L	DIESEL	SYSTEM SEARCH																																															
MONDEO	2010 MY	2.0L	DIESEL	PCM(PowerTrain Control Module)										V			V																													V	V				
MONDEO	2010 MY	2.0L	DIESEL	ABS(Anti-Lock Brake System)				V																		V				V	V	V	V	V	V	V															
MONDEO	2010 MY	2.0L	DIESEL	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	BCMii(Body Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	CCMii(Cruise Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	CMR(Camera Module Rear)																																															
MONDEO	2010 MY	2.0L	DIESEL	DDM(Driver's Door Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	DSM(Driver's Seat Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	HCM(Headlamp Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2010 MY	2.0L	DIESEL	IPC(Instrument Panel Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PAM(Parking Aid Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PBM(Parking Brake Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PDM(Passenger's Door Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PSCM(Power Steering Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	RCM(Restraint Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	RFA(Remote Function Actuator)																																															
MONDEO	2010 MY	2.0L	DIESEL	SASM(Steering Angle Sensor Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	SRM(Speech Recognition Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	TCM(Transmission Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	TRM(Trailer Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	VDM(Vehicle Dynamic Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)				V																		V	V			V	V	V	V	V	V	V														V		
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2010 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)					V																	V																												
MONDEO	2010 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2010 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2010 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2010 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2010 MY	2.5L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2010 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2010 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2010 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2010 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2010 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2010 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)				V																	V	V			V	V	V	V	V	V	V														V		
MONDEO	2009 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2009 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	2009 MY	1.8L DIESEL	PCM(PowerTrain Control Module)											V			V																															V	V			
MONDEO	2009 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)					V																		V				V	V	V	V	V	V	V															
MONDEO	2009 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	BCMii(Body Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																																
MONDEO	2009 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	1.8L DIESEL	TRM(Trailer Module)																																																
MONDEO	2009 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2009 MY	2.0L DIESEL	SYSTEM SEARCH																																																
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)											V			V																															V	V			
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)					V																		V				V	V	V	V	V	V	V															
MONDEO	2009 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																
MONDEO	2009 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2009 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	2.0L DIESEL	TRM(Trailer Module)																																																
MONDEO	2009 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2009 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)					V																	V																											
MONDEO	2009 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2009 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2009 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2009 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2009 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)				V																	V	V		V	V	V	V	V	V	V														V		
MONDEO	2008 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																
MONDEO	2008 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2008 MY	1.8L DIESEL	PCM(PowerTrain Control Module)											V			V																														V	V				
MONDEO	2008 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)					V																	V			V	V	V	V	V	V	V																V	
MONDEO	2008 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	BCMii(Body Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2008 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2008 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2008 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																	
MONDEO	2008 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	TRM(Trailer Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2008 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)					V																	V																												
MONDEO	2008 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2008 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2008 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2008 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2008 MY	2.5L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2008 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2008 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2008 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2008 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2008 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2008 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)				V																	V	V			V	V	V	V	V	V	V														V		
MONDEO	2007 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2007 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2007 MY	1.8L DIESEL	PCM(PowerTrain Control Module)											V			V																															V	V				
MONDEO	2007 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)					V																		V				V	V	V	V	V	V	V																
MONDEO	2007 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	BCMii(Body Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2007 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2007 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																	
MONDEO	2007 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	TRM(Trailer Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2007 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)					V																		V																											
MONDEO	2007 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2007 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2007 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2007 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2007 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2007 MY	2.5L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2007 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2007 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2007 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2007 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2007 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2003 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2003 MY	2.0L DIESEL	PCM(PowerTrain Control Module)															V																																		
MONDEO	2003 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2003 MY	2.0L DIESEL	CSM(Central Security Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2003 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2003 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																	
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2003 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																
MONDEO	2003 MY	2.0L DIESEL	ACM(Audio Control Module)																																																
MONDEO	2003 MY	2.0L DIESEL	CDP(Compact Disc Player)																																																
MONDEO	2003 MY	2.0L DIESEL	GDM(Generic Display Module)																																																
MONDEO	2003 MY	2.0L DIESEL	NAV(Navigation System)																																																
MONDEO	2003 MY	2.0L DIESEL	RETM(Rear Entertainment Module)																																																
MONDEO	2003 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2003 MY	2.0L DIESEL	ICU(Injector Control Unit)																																																
MONDEO	2003 MY	2.0L DIESEL	PATS(Passive Anti Theft System)																																																
MONDEO	2002 MY	2.0L DIESEL	SYSTEM SEARCH																																																
MONDEO	2002 MY	2.0L DIESEL	PCM(PowerTrain Control Module)															V																																	
MONDEO	2002 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2002 MY	2.0L DIESEL	CSM(Central Security Module)																																																
MONDEO	2002 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																
MONDEO	2002 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																
MONDEO	2002 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2002 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																
MONDEO	2002 MY	2.0L DIESEL	ACM(Audio Control Module)																																																
MONDEO	2002 MY	2.0L DIESEL	CDP(Compact Disc Player)																																																
MONDEO	2002 MY	2.0L DIESEL	GDM(Generic Display Module)																																																
MONDEO	2002 MY	2.0L DIESEL	NAV(Navigation System)																																																
MONDEO	2002 MY	2.0L DIESEL	RETM(Rear Entertainment Module)																																																
MONDEO	2002 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2002 MY	2.0L DIESEL	ICU(Injector Control Unit)																																																
MONDEO	2002 MY	2.0L DIESEL	PATS(Passive Anti Theft System)																																																
MONDEO	2002 MY	2.0L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2002 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2002 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2002 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																
MONDEO	2002 MY	2.0L GASOLINE	GEM(Generic Electronic Module)																																																
MONDEO	2002 MY	2.0L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2002 MY	2.0L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2001 MY	2.0L DIESEL	SYSTEM SEARCH																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	2001 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2001 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																
MONDEO	2001 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																
MONDEO	2001 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																
MONDEO	2001 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																
MONDEO	2001 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																
MONDEO	2001 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2001 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																
MONDEO	2001 MY	2.0L DIESEL	ACM(Audio Control Module)																																																
MONDEO	2001 MY	2.0L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2001 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2001 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2001 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																
MONDEO	2001 MY	2.0L GASOLINE	GEM(Generic Electronic Module)																																																
MONDEO	2001 MY	2.0L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2001 MY	2.0L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2000 MY	1.8L	SYSTEM SEARCH																																																
MONDEO	2000 MY	1.8L	PCM(PowerTrain Control Module)																																																
MONDEO	2000 MY	1.8L	ABS(Anti-Lock Brake System)																																																
MONDEO	2000 MY	1.8L	CSM(Central Security Module)																																																
MONDEO	2000 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	2000 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2000 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2000 MY	1.8L DIESEL	CSM(Central Security Module)																																																
MONDEO	2000 MY	1.8L DIESEL	Passive Antitheft																																																
MONDEO	2000 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																
MONDEO	2000 MY	2.0L	SYSTEM SEARCH																																																
MONDEO	2000 MY	2.0L	PCM(PowerTrain Control Module)																																																
MONDEO	2000 MY	2.0L	ABS(Anti-Lock Brake System)																																																
MONDEO	2000 MY	2.0L	CSM(Central Security Module)																																																
MONDEO	2000 MY	2.5L	SYSTEM SEARCH																																																
MONDEO	2000 MY	2.5L	PCM(PowerTrain Control Module)																																																
MONDEO	2000 MY	2.5L	ABS(Anti-Lock Brake System)																																																
MONDEO	2000 MY	2.5L	CSM(Central Security Module)																																																
MONDEO	1999 MY	1.8L	SYSTEM SEARCH																																																
MONDEO	1999 MY	1.8L	PCM(PowerTrain Control Module)																																																
MONDEO	1999 MY	1.8L	ABS(Anti-Lock Brake System)																																																
MONDEO	1999 MY	1.8L	CSM(Central Security Module)																																																
MONDEO	1999 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	1999 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MONDEO	1999 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	1999 MY	1.8L DIESEL	CSM(Central Security Module)																																																
MONDEO	1999 MY	1.8L DIESEL	Passive Antitheft																																																
MONDEO	1999 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																
MONDEO	1999 MY	2.0L	SYSTEM SEARCH																																																
MONDEO	1999 MY	2.0L	PCM(PowerTrain Control Module)																																																
MONDEO	1999 MY	2.0L	ABS(Anti-Lock Brake System)																																																
MONDEO	1999 MY	2.0L	CSM(Central Security Module)																																																
MONDEO	1999 MY	2.5L	SYSTEM SEARCH																																																
MONDEO	1999 MY	2.5L	PCM(PowerTrain Control Module)																																																
MONDEO	1999 MY	2.5L	ABS(Anti-Lock Brake System)																																																
MONDEO	1999 MY	2.5L	CSM(Central Security Module)																																																
MONDEO	1998 MY	1.8L	SYSTEM SEARCH																																																
MONDEO	1998 MY	1.8L	PCM(PowerTrain Control Module)																																																
MONDEO	1998 MY	1.8L	ABS(Anti-Lock Brake System)																																																
MONDEO	1998 MY	1.8L	CSM(Central Security Module)																																																
MONDEO	1998 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	1998 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	1998 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	1998 MY	1.8L DIESEL	CSM(Central Security Module)																																																
MONDEO	1998 MY	1.8L DIESEL	Passive Antitheft																																																
MONDEO	1998 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																
MONDEO	1998 MY	2.0L	SYSTEM SEARCH																																																
MONDEO	1998 MY	2.0L	PCM(PowerTrain Control Module)																																																
MONDEO	1998 MY	2.0L	ABS(Anti-Lock Brake System)																																																
MONDEO	1998 MY	2.0L	CSM(Central Security Module)																																																
MONDEO	1998 MY	2.5L	SYSTEM SEARCH																																																
MONDEO	1998 MY	2.5L	PCM(PowerTrain Control Module)																																																
MONDEO	1998 MY	2.5L	ABS(Anti-Lock Brake System)																																																
MONDEO	1998 MY	2.5L	CSM(Central Security Module)																																																
MONDEO	1997 MY	1.8L	PCM(PowerTrain Control Module)																																																
MONDEO	1997 MY	1.8L	ABS(Anti-Lock Brake System)																																																
MONDEO	1997 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	1997 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	1997 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	1997 MY	1.8L DIESEL	Passive Antitheft																																																
MONDEO	1997 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																
MONDEO	1997 MY	2.0L	PCM(PowerTrain Control Module)																																																
MONDEO	1997 MY	2.0L	ABS(Anti-Lock Brake System)																																																
MONDEO	1997 MY	2.5L	PCM(PowerTrain Control Module)																																																
MONDEO	1997 MY	2.5L	ABS(Anti-Lock Brake System)																																																
MOUNTAINEER	2010 MY	4.6L	SYSTEM SEARCH																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MOUNTAINEER	2010 MY	4.6L	PCM(Powertrain Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	TCM(Transmission Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	4X4(4x4 Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
MOUNTAINEER	2010 MY	4.6L	ACM(Audio Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
MOUNTAINEER	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																	
MOUNTAINEER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
MOUNTAINEER	2010 MY	4.6L	DSM(Driver's Seat Module)																																																	
MOUNTAINEER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
MOUNTAINEER	2010 MY	4.6L	IC(Instrument Cluster)																																																	
MOUNTAINEER	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
MOUNTAINEER	2010 MY	4.6L	PAM(Parking Aid Module)																																																	
MOUNTAINEER	2010 MY	4.6L	PRB(Power Running Board)																																																	
MOUNTAINEER	2010 MY	4.6L	RCM(Restraint Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																	
MOUNTAINEER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
MOUNTAINEER	2009 MY	4.6L	SYSTEM SEARCH																																																	
MOUNTAINEER	2009 MY	4.6L	PCM(Powertrain Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	TCM(Transmission Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	4X4(4x4 Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
MOUNTAINEER	2009 MY	4.6L	ACM(Audio Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
MOUNTAINEER	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																	
MOUNTAINEER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
MOUNTAINEER	2009 MY	4.6L	DSM(Driver's Seat Module)																																																	
MOUNTAINEER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
MOUNTAINEER	2009 MY	4.6L	IC(Instrument Cluster)																																																	
MOUNTAINEER	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
MOUNTAINEER	2009 MY	4.6L	PAM(Parking Aid Module)																																																	
MOUNTAINEER	2009 MY	4.6L	PRB(Power Running Board)																																																	
MOUNTAINEER	2009 MY	4.6L	RCM(Restraint Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																	
MOUNTAINEER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
MUSTANG	4.0L V6 SOHC			SYSTEM SEARCH																																																
MUSTANG	4.0L V6 SOHC			PCM(Powertrain Control Module)																																																	
MUSTANG	4.0L V6 SOHC			ABS(Anti-Lock Brake System)																																																	
MUSTANG	4.0L V6 SOHC			ACM(Audio Control Module)																																																	
MUSTANG	4.0L V6 SOHC			APIM(Accessory Protocol Interface Module)																																																	
MUSTANG	4.0L V6 SOHC			GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
MUSTANG	4.0L V6 SOHC			RCM(Restraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
MUSTANG	4.0L V6 SOHC			SDARS(Satellite Digital Audio Receiver System)																																																
MUSTANG	4.0L V6 SOHC			IC(Instrument Cluster)																																																
TAURUS	2011 MY	3.5L	SYSTEM SEARCH																																																	
TAURUS	2011 MY	3.5L	PCM(PowerTrain Control Module)																																																	
TAURUS	2011 MY	3.5L	4X4(4x4 Control Module)																																																	
TAURUS	2011 MY	3.5L	ABS(Anti-Lock Brake System)																																																	
TAURUS	2011 MY	3.5L	ACM(Audio Control Module)																																																	
TAURUS	2011 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																	
TAURUS	2011 MY	3.5L	C-CM(Cruise Control Module)																																																	
TAURUS	2011 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																	
TAURUS	2011 MY	3.5L	DDM(Driver's Door Module)																																																	
TAURUS	2011 MY	3.5L	DSM(Driver's Seat Module)																																																	
TAURUS	2011 MY	3.5L	DSP(Digital Signal Processing Module)																																																	
TAURUS	2011 MY	3.5L	FCIM(Front Controls Interface Module)																																																	
TAURUS	2011 MY	3.5L	FDIM(Front Display Interface Module)																																																	
TAURUS	2011 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
TAURUS	2011 MY	3.5L	GPSM(Global Positioning System Module)																																																	
TAURUS	2011 MY	3.5L	HCM(Headlamp Control Module)																																																	
TAURUS	2011 MY	3.5L	HCM-2(Headlamp Control Module2)																																																	
TAURUS	2011 MY	3.5L	HUD(Head Up Display)																																																	
TAURUS	2011 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																	
TAURUS	2011 MY	3.5L	ILCM(Interior Lighting Control Module)																																																	
TAURUS	2011 MY	3.5L	IPC(Instrument Panel Control Module)																																																	
TAURUS	2011 MY	3.5L	OCSM(Occupant Classification System Module)																																																	
TAURUS	2011 MY	3.5L	PAM(Parking Aid Module)																																																	
TAURUS	2011 MY	3.5L	PSCM(Power Steering Control Module)																																																	
TAURUS	2011 MY	3.5L	RCM(Restraint Control Module)																																																	
TAURUS	2011 MY	3.5L	RETM(Rear Entertainment Module)																																																	
TAURUS	2011 MY	3.5L	RFA(Remote Function Actuator)																																																	
TAURUS	2011 MY	3.5L	SASM(Steering Angle Sensor Module)																																																	
TAURUS	2011 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																	
TAURUS	2011 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																	
TAURUS	2010 MY	3.5L	SYSTEM SEARCH																																																	
TAURUS	2010 MY	3.5L	PCM(PowerTrain Control Module)																																																	
TAURUS	2010 MY	3.5L	4X4(4x4 Control Module)																																																	
TAURUS	2010 MY	3.5L	ABS(Anti-Lock Brake System)																																																	
TAURUS	2010 MY	3.5L	ACM(Audio Control Module)																																																	
TAURUS	2010 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																	
TAURUS	2010 MY	3.5L	C-CM(Cruise Control Module)																																																	
TAURUS	2010 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																	
TAURUS	2010 MY	3.5L	DDM(Driver's Door Module)																																																	
TAURUS	2010 MY	3.5L	DSM(Driver's Seat Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
TAURUS	2010 MY	3.5L	DSP(Digital Signal Processing Module)																																																	
TAURUS	2010 MY	3.5L	FCIM(Front Controls Interface Module)																																																	
TAURUS	2010 MY	3.5L	FDIM(Front Display Interface Module)																																																	
TAURUS	2010 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
TAURUS	2010 MY	3.5L	GPSM(Global Positioning System Module)																																																	
TAURUS	2010 MY	3.5L	HCM(Headlamp Control Module)																																																	
TAURUS	2010 MY	3.5L	HCM-2(Headlamp Control Module2)																																																	
TAURUS	2010 MY	3.5L	HUD(Head Up Display)																																																	
TAURUS	2010 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																	
TAURUS	2010 MY	3.5L	ILCM(Interior Lighting Control Module)																																																	
TAURUS	2010 MY	3.5L	IPC(Instrument Panel Control Module)																																																	
TAURUS	2010 MY	3.5L	OCSM(Occupant Classification System Module)																																																	
TAURUS	2010 MY	3.5L	PAM(Parking Aid Module)																																																	
TAURUS	2010 MY	3.5L	PSCM(Power Steering Control Module)																																																	
TAURUS	2010 MY	3.5L	RCM(Restraint Control Module)																																																	
TAURUS	2010 MY	3.5L	RETM(Rear Entertainment Module)																																																	
TAURUS	2010 MY	3.5L	RFA(Remote Function Actuator)																																																	
TAURUS	2010 MY	3.5L	SASM(Steering Angle Sensor Module)																																																	
TAURUS	2010 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																	
TAURUS	2010 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																	
TAURUS	2009 MY	3.5L	SYSTEM SEARCH																																																	
TAURUS	2009 MY	3.5L	PCM(PowerTrain Control Module)																																																	
TAURUS	2009 MY	3.5L	4X4(4x4 Control Module)																																																	
TAURUS	2009 MY	3.5L	ABS(Anti-Lock Brake System)																																																	
TAURUS	2009 MY	3.5L	ACM(Audio Control Module)																																																	
TAURUS	2009 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																	
TAURUS	2009 MY	3.5L	C-CM(Cruise Control Module)																																																	
TAURUS	2009 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																	
TAURUS	2009 MY	3.5L	DDM(Driver's Door Module)																																																	
TAURUS	2009 MY	3.5L	DSM(Driver's Seat Module)																																																	
TAURUS	2009 MY	3.5L	DSP(Digital Signal Processing Module)																																																	
TAURUS	2009 MY	3.5L	FCIM(Front Controls Interface Module)																																																	
TAURUS	2009 MY	3.5L	FDIM(Front Display Interface Module)																																																	
TAURUS	2009 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
TAURUS	2009 MY	3.5L	GPSM(Global Positioning System Module)																																																	
TAURUS	2009 MY	3.5L	HCM(Headlamp Control Module)																																																	
TAURUS	2009 MY	3.5L	HCM-2(Headlamp Control Module2)																																																	
TAURUS	2009 MY	3.5L	HUD(Head Up Display)																																																	
TAURUS	2009 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																	
TAURUS	2009 MY	3.5L	ILCM(Interior Lighting Control Module)																																																	
TAURUS	2009 MY	3.5L	IPC(Instrument Panel Control Module)																																																	
TAURUS	2009 MY	3.5L	OCSM(Occupant Classification System Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
TAURUS	2009 MY	3.5L	PAM(Parking Aid Module)																																																	
TAURUS	2009 MY	3.5L	PSCM(Power Steering Control Module)																																																	
TAURUS	2009 MY	3.5L	RCM(Restraint Control Module)																																																	
TAURUS	2009 MY	3.5L	RETM(Rear Entertainment Module)																																																	
TAURUS	2009 MY	3.5L	RFA(Remote Function Actuator)																																																	
TAURUS	2009 MY	3.5L	SASM(Steering Angle Sensor Module)																																																	
TAURUS	2009 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																	
TAURUS	2009 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																	
TAURUS	2008 MY	3.5L	SYSTEM SEARCH																																																	
TAURUS	2008 MY	3.5L	PCM(PowerTrain Control Module)																																																	
TAURUS	2008 MY	3.5L	4X4(4x4 Control Module)																																																	
TAURUS	2008 MY	3.5L	ABS(Anti-Lock Brake System)																																																	
TAURUS	2008 MY	3.5L	ACM(Audio Control Module)																																																	
TAURUS	2008 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																	
TAURUS	2008 MY	3.5L	C-CM(Cruise Control Module)																																																	
TAURUS	2008 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																	
TAURUS	2008 MY	3.5L	DDM(Driver's Door Module)																																																	
TAURUS	2008 MY	3.5L	DSM(Driver's Seat Module)																																																	
TAURUS	2008 MY	3.5L	DSP(Digital Signal Processing Module)																																																	
TAURUS	2008 MY	3.5L	FCIM(Front Controls Interface Module)																																																	
TAURUS	2008 MY	3.5L	FDIM(Front Display Interface Module)																																																	
TAURUS	2008 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
TAURUS	2008 MY	3.5L	GPSM(Global Positioning System Module)																																																	
TAURUS	2008 MY	3.5L	HCM(Headlamp Control Module)																																																	
TAURUS	2008 MY	3.5L	HCM-2(Headlamp Control Module2)																																																	
TAURUS	2008 MY	3.5L	HUD(Head Up Display)																																																	
TAURUS	2008 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																	
TAURUS	2008 MY	3.5L	ILCM(Interior Lighting Control Module)																																																	
TAURUS	2008 MY	3.5L	IPC(Instrument Panel Control Module)																																																	
TAURUS	2008 MY	3.5L	OCSM(Occupant Classification System Module)																																																	
TAURUS	2008 MY	3.5L	PAM(Parking Aid Module)																																																	
TAURUS	2008 MY	3.5L	PSCM(Power Steering Control Module)																																																	
TAURUS	2008 MY	3.5L	RCM(Restraint Control Module)																																																	
TAURUS	2008 MY	3.5L	RETM(Rear Entertainment Module)																																																	
TAURUS	2008 MY	3.5L	RFA(Remote Function Actuator)																																																	
TAURUS	2008 MY	3.5L	SASM(Steering Angle Sensor Module)																																																	
TAURUS	2008 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																	
TAURUS	2008 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																	
TAURUS	1998 MY	SYSTEM SEARCH																																																		
TAURUS	1998 MY	PCM(PowerTrain Control Module)																																																		
TAURUS	1998 MY	ABS(Anti-Lock Brake System)																																																		
TAURUS	1998 MY	RCM(Restraint Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
TAURUS	1998 MY	RIM(Remote Immobilizer Module)																																																		
TAURUS	1997 MY	SYSTEM SEARCH																																																		
TAURUS	1997 MY	PCM(PowerTrain Control Module)																																																		
TAURUS	1997 MY	ABS(Anti-Lock Brake System)																																																		
TAURUS	1997 MY	RCM(Restraint Control Module)																																																		
TAURUS	1997 MY	RIM(Remote Immobilizer Module)																																																		
TAURUS	1996 MY	SYSTEM SEARCH																																																		
TAURUS	1996 MY	PCM(PowerTrain Control Module)																																																		
TAURUS	1996 MY	ABS(Anti-Lock Brake System)																																																		
TAURUS	1996 MY	RCM(Restraint Control Module)																																																		
TAURUS	1996 MY	RIM(Remote Immobilizer Module)																																																		
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	SYSTEM SEARCH																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PCM(PowerTrain Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	TCM(Transmission Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ABS(Anti-Lock Brake System)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ACM(Audio Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	APIM(Accessory Protocol Interface Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	BEM(Body Electronic Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	FCIM(Front Controls Interface Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GPSM(Global Positioning System Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GWM(Gateway Module A)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	HIM(HVAC Integrated Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	IPC(Instrument Panel Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PAM(Parking Aid Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PSCM(Power Steering Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	RCM(Restraint Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	SYSTEM SEARCH																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PCM(Powertrain Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	TCM(Transmission Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	ACM(Audio Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PSCM(Power Steering Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	HIM(HVAC Integrated Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
TERRITORY	2010~	4.0L GASOLINE	SY	FDIM(Front Display Interface Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	SYSTEM SEARCH																																															
TERRITORY	2010~	2.7L DIESEL	SZ	PCM(Powertrain Control Module)													V																														V				
TERRITORY	2010~	2.7L DIESEL	SZ	ABS(Anti-Lock Brake System)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	ACM(Audio Control Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	AWD(All Wheel Drive Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	BEM(Body Electronic Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	FDIM(Front Display Interface Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	HIM(HVAC Intergrated Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	IPC(Instrument Panel Control Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	PAM(Parking Aid Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	PSCM(Power Steering Control Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	RCM(Restraint Control Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	TCM(Transmission Control Module)																																															
TERRITORY	2009~2010	SYSTEM SEARCH																																																	
TERRITORY	2009~2010	PCM(PowerTrain Control Module)																																																	
TERRITORY	2009~2010	TCM(Transmission Control Module)																																																	
TERRITORY	2009~2010	ABS(Anti-Lock Brake System)																																												V					
TERRITORY	2009~2010	RCM(Restraint Control Module)																																																	
TERRITORY	2009~2010	BEM(Body Electronic Module)																																																	
TERRITORY	2009~2010	IC(Instrument Cluster)																																																	
TERRITORY	2009~2010	HIM(HVAC Integrated Module)																																												V					
TERRITORY	2009~2010	ACM(Audio Control Module)																																																	
TERRITORY	2005~2009	SYSTEM SEARCH																																																	
TERRITORY	2005~2009	PCM(PowerTrain Control Module)																																																	
TERRITORY	2005~2009	TCM(Transmission Control Module)																																																	
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)																																												V					
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)																																																	
TERRITORY	2005~2009	RCM(Restraint Control Module)																																																	
TERRITORY	2005~2009	BEM(Body Electronic Module)																																																	
TERRITORY	2005~2009	IC(Instrument Cluster)																																																	
TERRITORY	2005~2009	HIM(HVAC Integrated Module)																																												V					
TERRITORY	2005~2009	ACM(Audio Control Module)																																																	
TERRITORY	2004~2005	SYSTEM SEARCH																																																	
TERRITORY	2004~2005	PCM(PowerTrain Control Module)																																																	
TERRITORY	2004~2005	ABS(Anti-Lock Brake System)																																																	
TERRITORY	2004~2005	RCM(Restraint Control Module)																																																	
TERRITORY	2004~2005	BEM(Body Electronic Module)																																																	
TERRITORY	2004~2005	IC(Instrument Cluster)																																																	
TERRITORY	2004~2005	HIM(HVAC Integrated Module)																																												V					
TERRITORY	2004~2005	HIM(HVAC Integrated Module)																																												V					
TERRITORY	2004~2005	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
TERRITORY	2004~2005	PAM(Parking Aid Module)																																																		
TRANSIT	1.6L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	1.6L DIESEL	PCM(PowerTrain Control Module)													V		V	V	V		V	V		V	V																					V					
TRANSIT	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																		
TRANSIT	1.6L DIESEL	ACM(Audio Control Module)																																																		
TRANSIT	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
TRANSIT	1.6L DIESEL	APIM(Accessory Protocol Interface Module)																																																		
TRANSIT	1.6L DIESEL	BCMii(Body Control Module)																																																		
TRANSIT	1.6L DIESEL	DDM(Driver's Door Module)																																																		
TRANSIT	1.6L DIESEL	FCIM(Front Controls Interface Module)																																																		
TRANSIT	1.6L DIESEL	FDSM(Front Distance Sensing Module)																																																		
TRANSIT	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)																																																		
TRANSIT	1.6L DIESEL	GPSM(Global Positioning System Module)																																																		
TRANSIT	1.6L DIESEL	HCM(Headlamp Control Module)																																																		
TRANSIT	1.6L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
TRANSIT	1.6L DIESEL	IPM-B(Image Processing Module B)																																																		
TRANSIT	1.6L DIESEL	IPC(Instrument Panel Control Module)																																																		
TRANSIT	1.6L DIESEL	PAM(Parking Aid Module)																																																		
TRANSIT	1.6L DIESEL	PDM(Passenger's Door Module)																																																		
TRANSIT	1.6L DIESEL	PSCM(Power Steering Control Module)																																																		
TRANSIT	1.6L DIESEL	RCM(Restraint Control Module)										V	V																																							
TRANSIT	1.6L DIESEL	SASM(Steering Angle Sensor Module)																																																		
TRANSIT	1.6L DIESEL	TRM(Trailer Module)																																																		
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																											V					
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																														V		
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																								V																								
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)																																											V					
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)																																															
TRANSIT	2.0L	SYSTEM SEARCH																																																	
TRANSIT	2.0L	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.0L	PATS(Passive Anti Theft System)																										V																							
TRANSIT	2.0L	ASM(Auto Shift Manual)																																																	
TRANSIT	2.0L	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.0L	HEC(Hybrid Electrical Cluster)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SYSTEM SEARCH																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PCM(PowerTrain Control Module)											V		V	V	V		V			V																							V					
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)	V	V																																														
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ACM(Audio Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	APIM(Accessory Protocol Interface Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	AHCM(Auxiliary Heater Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	CCMii(Cruise Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FCDIM(Front Control/Display Interface Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	GPSM(Global Positioning System Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	HCM(Headlamp Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-A(Image Processing Module A)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-B(Image Processing Module B)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FFH(Fuel Fired Coolant Heating Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PRB(Power Running Board)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SRM(Speech Recognition Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SASM(Steering Angle Sensor Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TBC(Trailer Brake Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TRM(Trailer Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SYSTEM SEARCH																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PCM(PowerTrain Control Module)											V		V	V	V		V			V																							V					
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)	V	V																																														
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ACM(Audio Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	APIM(Accessory Protocol Interface Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	AHCM(Auxiliary Heater Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	CCMii(Cruise Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FCDIM(Front Control/Display Interface Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	GPSM(Global Positioning System Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	HCM(Headlamp Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-A(Image Processing Module A)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-B(Image Processing Module B)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FFH(Fuel Fired Coolant Heating Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PRB(Power Running Board)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SRM(Speech Recognition Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SASM(Steering Angle Sensor Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TBC(Trailer Brake Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TRM(Trailer Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	SYSTEM SEARCH																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PATS(Passive Anti Theft System)																								V																								
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ASM(Auto Shift Manual)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	HEC(Hybrid Electrical Cluster)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	BCMii(Body Control Module)																								V																								
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	CSM(Central Security Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ACM(Audio Control Module)																																																
TRANSIT	2.3L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.3L DIESEL	PATS(Passive Anti Theft System)																										V																								
TRANSIT	2.3L DIESEL	ASM(Auto Shift Manual)																																																		
TRANSIT	2.3L DIESEL	ABS(Anti-Lock Brake System)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
TRANSIT	2.3L DIESEL	RCM(Restraint Control Module)																																																		
TRANSIT	2.3L DIESEL	HEC(Hybrid Electrical Cluster)																																																		
TRANSIT	2.3L DIESEL	IPC(Instrument Panel Control Module)																																																		
TRANSIT	2.3L DIESEL	BCMii(Body Control Module)																										V																								
TRANSIT	2.3L DIESEL	ACM(Audio Control Module)																																																		
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)		V	V																																														
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	BCMii(Body Control Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	IPC(Instrument Panel Control Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)																																																	
TRANSIT	2.4L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.4L DIESEL	PATS(Passive Anti Theft System)																										V																								
TRANSIT	2.4L DIESEL	ASM(Auto Shift Manual)																																																		
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)																																																		
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)																																																		
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)																																																		
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)																																																		
TRANSIT	2.4L DIESEL	HEC(Hybrid Electrical Cluster)																																																		
TRANSIT	2.4L DIESEL	IPC(Instrument Panel Control Module)																																																		
TRANSIT	2.4L DIESEL	BCMii(Body Control Module)																										V																								
TRANSIT	2.4L DIESEL	CSM(Central Security Module)																																																		
TRANSIT	2.4L DIESEL	ACM(Audio Control Module)																																																		
TRANSIT	2.5L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.5L DIESEL	PATS(Passive Anti Theft System)																										V																								
TRANSIT	2.5L DIESEL	ASM(Auto Shift Manual)																																																		
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																																																	
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																																																	
TRANSIT	2.5L DIESEL	RCM(Restraint Control Module)																																																		
TRANSIT	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																																																		
TRANSIT	2.5L DIESEL	CSM(Central Security Module)																																																		
TRANSIT	2.5L DIESEL	Passive Antitheft																																																		
TRANSIT	2.5L DIESEL	RIM(Remote Immobilizer Module)																																																		
TRANSIT	2.5L DIESEL	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
TRANSIT	3.2L DIESEL	SYSTEM SEARCH																																																	
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	3.2L DIESEL	ABS(Anti-Lock Brake System)																																																	
TRANSIT	3.2L DIESEL	ACM(Audio Control Module)																																																	
TRANSIT	3.2L DIESEL	BCMii(Body Control Module)																																																	
TRANSIT	3.2L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
TRANSIT	3.2L DIESEL	IPC(Instrument Panel Control Module)																																																	
TRANSIT	3.2L DIESEL	PAM(Parking Aid Module)																																																	
TRANSIT	3.2L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	3.2L DIESEL	SRM(Speech Recognition Module)																																																	
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																											V				
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																													V		
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																								V																							
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)																																											V				
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)																																													V		
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)																																															
RANGER	2.2 Diesel	SYSTEM SEARCH																																																	
RANGER	2.2 Diesel	PCM(PowerTrain Control Module)													V		V	V	V		V			V	V																					V						
RANGER	2.2 Diesel	ABS(Anti-Lock Brake System)																																																	
RANGER	2.2 Diesel	ACM(Audio Control Module)																																																	
RANGER	2.2 Diesel	BCMii(Body Control Module)																																																	
RANGER	2.2 Diesel	DDM(Driver's Door Module)																																																	
RANGER	2.2 Diesel	FCDIM(Front Control/Display Interface Module)																																																	
RANGER	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
RANGER	2.2 Diesel	IPC(Instrument Panel Control Module)																																																		
RANGER	2.2 Diesel	PAM(Parking Aid Module)																																																		
RANGER	2.2 Diesel	PDM(Passenger's Door Module)																																																		
RANGER	2.2 Diesel	RCM(Restraint Control Module)																																																		
RANGER	2.2 Diesel	SRM(Speech Recognition Module)																																																		
RANGER	2.2 Diesel	TBM(Tracking And Blocking Module)																																																		
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																		
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																		
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																		
RANGER	2.2 Diesel	TRM(Trailer Module)																																																		
RANGER	2.2 Diesel	PATS(Passive anti theft system)-BETA																																																		
RANGER	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																																		
RANGER	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)												V																																						
RANGER	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																																																		
RANGER	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																																																		
RANGER	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																																																		
RANGER	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)-BETA																																																		
RANGER	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																																		
RANGER	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)												V																																						
RANGER	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																																																		
RANGER	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																																																		
RANGER	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																																																		
RANGER	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)-BETA																																																		
RANGER	3.2 Diesel	~ 2015	SYSTEM SEARCH																																																	
RANGER	3.2 Diesel	~ 2015	PCM(PowerTrain Control Module)												V		V	V	V		V			V	V																					V						
RANGER	3.2 Diesel	~ 2015	ABS(Anti-Lock Brake System)																																																	
RANGER	3.2 Diesel	~ 2015	ACM(Audio Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	BCMii(Body Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	DDM(Driver's Door Module)																																																	
RANGER	3.2 Diesel	~ 2015	FCDIM(Front Control/Display Interface Module)																																																	
RANGER	3.2 Diesel	~ 2015	HVAC(Heating Ventilation Air Conditioning)																																																	
RANGER	3.2 Diesel	~ 2015	IPC(Instrument Panel Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	PAM(Parking Aid Module)																																																	
RANGER	3.2 Diesel	~ 2015	PDM(Passenger's Door Module)																																																	
RANGER	3.2 Diesel	~ 2015	RCM(Restraint Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	SRM(Speech Recognition Module)																																																	
RANGER	3.2 Diesel	~ 2015	TBM(Tracking And Blocking Module)																																																	
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	TRM(Trailer Module)																																																	
RANGER	3.2 Diesel	~ 2015	PATS(Passive anti theft system)-BETA																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
RANGER	3.2 Diesel	2015 ~	SYSTEM SEARCH																																																	
RANGER	3.2 Diesel	2015 ~	PCM(PowerTrain Control Module)												V		V				V			V																												
RANGER	3.2 Diesel	2015 ~	TCM(Transmission Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	ABS(Anti-Lock Brake System)																																									V								
RANGER	3.2 Diesel	2015 ~	ACM(Audio Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	APIM(Accessory Protocol Interface Module)																																																	
RANGER	3.2 Diesel	2015 ~	ATCM(All Terrain Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	BCM(Body Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	C-CM(Cruise Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	DDM(Driver's Door Module)																																																	
RANGER	3.2 Diesel	2015 ~	FCDIM(Front Control/Display Interface Module)																																																	
RANGER	3.2 Diesel	2015 ~	FCIM(Front Controls Interface Module)																																																	
RANGER	3.2 Diesel	2015 ~	GPSM(Global Positioning System Module)																																																	
RANGER	3.2 Diesel	2015 ~	GWM(Gateway Module A)																																																	
RANGER	3.2 Diesel	2015 ~	HCM(Headlamp Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	HUD(Head Up Display)																																																	
RANGER	3.2 Diesel	2015 ~	IPC(Instrument Panel Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	IPM-A(Image Processing Module A)																																																	
RANGER	3.2 Diesel	2015 ~	PAM(Parking Aid Module)																																																	
RANGER	3.2 Diesel	2015 ~	PDM(Passenger's Door Module)																																																	
RANGER	3.2 Diesel	2015 ~	PSCM(Power Steering Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	RCM(Restraint Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	RGTM(Rear Gate/Trunk Module)																																																	
RANGER	3.2 Diesel	2015 ~	RTM(Radio Transceiver Module)																																																	
RANGER	3.2 Diesel	2015 ~	SCCM(Streering Colume Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	TCU(Telemetic Control Unit Module)																																																	
RANGER	3.2 Diesel	2015 ~	TRM(Trailer Module)																																																	
RANGER	2.5 Gasoline	SYSTEM SEARCH																																																		
RANGER	2.5 Gasoline	PCM(PowerTrain Control Module)																							V																												
RANGER	2.5 Gasoline	ABS(Anti-Lock Brake System)																																																		
RANGER	2.5 Gasoline	ACM(Audio Control Module)																																																		
RANGER	2.5 Gasoline	BCMii(Body Control Module)																																																		
RANGER	2.5 Gasoline	DDM(Driver's Door Module)																																																		
RANGER	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																																																		
RANGER	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																																																		
RANGER	2.5 Gasoline	IPC(Instrument Panel Control Module)																																																		
RANGER	2.5 Gasoline	PAM(Parking Aid Module)																																																		
RANGER	2.5 Gasoline	PDM(Passenger's Door Module)																																																		
RANGER	2.5 Gasoline	RCM(Restraint Control Module)																																																		
RANGER	2.5 Gasoline	SRM(Speech Recognition Module)																																																		
RANGER	2.5 Gasoline	TBM(Tracking And Blocking Module)																																																		
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																		
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																		
RANGER	2.5 Gasoline	TRM(Trailer Module)																																																		
RANGER	2.5 Gasoline	PATS(Passive anti theft system)-BETA																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	ABS(Anti-Lock Brake System)																																											V							
BETA-TEST	FOCUS-1.6L Zetec Rocam	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	MC(Message Center)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CMR(Camera Module Rear)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	D_DCU(Driver Door Control Unit)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EPS(Electronic Power Steering)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GDM(Generic Display Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	NAV(Navigation System)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RL_DCU(Rear Left Door Control Unit)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RR_DCU(Rear Right Door Control Unit)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	TCM(Transmission Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CMR(Camera Module Rear)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	D_DCU(Driver Door Control Unit)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EPS(Electronic Power Steering)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FACM(Fuel Additive Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EPS(Electronic Power Steering)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GDM(Generic Display Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	NAV(Navigation System)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SRM(Speech Recognition Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	TCM(Transmission Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																												V						
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																												V						
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EPS(Electronic Power Steering)																																												V						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GDM(Generic Display Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GEM(Generic Electronic Module)																																											V						
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	IC(Instrument Cluster)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	NAV(Navigation System)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PAM(Parking Aid Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PDM(Passenger's Door Module)																																											V						
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RL_DCU(Rear Left Door Control Unit)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RR_DCU(Rear Right Door Control Unit)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SRM(Speech Recognition Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	HCM(Headlamp Control Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RCM(Restraint Control Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	SYSTEM SEARCH																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PCM(Powertrain Control Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ACM(Audio Control Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	D_DCU(Driver Door Control Unit)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EPS(Electronic power steering)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	GEM(Generic Electronic Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	HCM(Headlamp Control Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	IC(Instrument Cluster)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PAM(Parking Aid Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PDM(Passenger's Door Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RCM(Restraint Control Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RKE(Remote Keyless Entry)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TBM(Tracking and Blocking Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TCM(Transmission Control Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PATS(Passive Anti Theft System)																																																V	V
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	SYSTEM SEARCH																																																	
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PCM(PowerTrain Control Module)												V																																					
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CDP(Compact Disc Player)																																																	
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CMR(Camera Module Rear)																																																	
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	D_DCU(Driver Door Control Unit)																																																	
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EPS(Electronic Power Steering)																																																	
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FACM(Fuel Additive Control Module)																																																	
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)																																																	
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	GEM(Generic Electronic Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FUSION GASOLINE1.4L	SYSTEM SEARCH																																																		
BETA-TEST	FUSION GASOLINE1.4L	PCM(Powertrain Control Module)																							V																												
BETA-TEST	FUSION GASOLINE1.4L	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FUSION GASOLINE1.4L	ACM(Audio Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	APIM(Accessory Protocol Interface Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	BCMii(Body Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	DDM(Driver's Door Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	FDSM(Front Distance Sensing Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	FCDIM(Front Control/Display Interface Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	GPSM(Global Positioning System Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	GWM(Gateway Module A)																																																		
BETA-TEST	FUSION GASOLINE1.4L	HVAC(Heating Ventilation Air Conditioning)																																																		
BETA-TEST	FUSION GASOLINE1.4L	IPC(Instrument Panel Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	PDM(Passenger's Door Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	PSCM(Power Steering Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	RCM(Restraint Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	RFA(Remote Function Actuator)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)															V																														V	V					
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	TCM(Transmission Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)																																				V														
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)																																											V				V	V		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IC(Instrument Cluster)																																												V						
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	GEM(Generic Electronic Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ACM(Audio Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	BCMii(Body Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	FCDIM(Front Control/Display Interface Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IPC(Instrument Panel Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PSCM(Power Steering Control Module)																																				V	V														
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RCM(Retraint Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RFA(Remote Function Actuator)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SRM(Speech Recognition Module)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SYSTEM SEARCH																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)																																																	
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	TCM(Transmission Control Module)																																																	
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)																																										V				V	V		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	IC(Instrument Cluster)																																																	
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ACM(Audio Control Module)																																																	
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)																																																	
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)																																																	
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																																	
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																	
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																																																	
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																																										V				V	V		
BETA-TEST	FIESTA 1.6L DURATEC 16V	SYSTEM SEARCH																																																	
BETA-TEST	FIESTA 1.6L DURATEC 16V	PCM(PowerTrain Control Module)																																																	
BETA-TEST	FIESTA 1.6L DURATEC 16V	TCM(Transmission Control Module)																																									V								
BETA-TEST	FIESTA 1.6L DURATEC 16V	ABS(Anti-Lock Brake System)																																										V				V	V		
BETA-TEST	FIESTA 1.6L DURATEC 16V	IC(Instrument Cluster)																																																	
BETA-TEST	FIESTA 1.6L DURATEC 16V	ACM(Audio Control Module)																																											V						
BETA-TEST	FIESTA 1.6L DURATEC 16V	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	FIESTA 1.6L DURATEC 16V	GEM(Generic Electronic Module)																																											V						
BETA-TEST	FIESTA 1.6L DURATEC 16V	SRM(Speech Recognition Module)																																																	
BETA-TEST	FIESTA 1.6L DURATEC 16V	PATS(Passive Anti Theft System)																																																V	V
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SYSTEM SEARCH																																																	
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PCM(PowerTrain Control Module)																																																	
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ABS(Anti-Lock Brake System)																																										V				V	V		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ACM(Audio Control Module)																																																	
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	GEM(Generic Electronic Module)																																																	
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	IC(Instrument Cluster)																																																	
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SRM(Speech Recognition Module)																																																	
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PATS(Passive Anti Theft System)																																																V	V
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	SYSTEM SEARCH																																																	
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PCM(PowerTrain Control Module)																																																	
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	ABS(Anti-Lock Brake System)																																										V				V	V		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	IC(Instrument Cluster)																																																	
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RCM(Restraint Control Module)																																																	
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RKE(Remote Keyless Entry)																																																	
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	TCM(Transmission Control Module)																																																	
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PATS(Passive Anti Theft System)																																																V	V
BETA-TEST	MONDEO-2.0L DIESEL	SYSTEM SEARCH																																																	
BETA-TEST	MONDEO-2.0L DIESEL	PCM(PowerTrain Control Module)												V			V																													V	V				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
BETA-TEST	MONDEO-2.0L DIESEL	ABS(Anti-Lock Brake System)						V																		V				V	V	V	V	V	V	V																
BETA-TEST	MONDEO-2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	BCMii(Body Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	CCMii(Cruise Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	CMR(Camera Module Rear)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	DDM(Driver's Door Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	DSM(Driver's Seat Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	HCM(Headlamp Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	IPC(Instrument Panel Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	PAM(Parking Aid Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	PBM(Parking Brake Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	PDM(Passenger's Door Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	PSCM(Power Steering Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	RCM(Restraint Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	RFA(Remote Function Actuator)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	SRM(Speech Recognition Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	TCM(Transmission Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	TRM(Trailer Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	SYSTEM SEARCH																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	PCM(PowerTrain Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	BCMii(Body Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	CCMii(Cruise Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	CMR(Camera Module Rear)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	DDM(Driver's Door Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	DSM(Driver's Seat Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	HCM(Headlamp Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	PAM(Parking Aid Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	PBM(Parking Brake Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	PDM(Passenger's Door Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	PSCM(Power Steering Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	RCM(Restraint Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	RFA(Remote Function Actuator)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	SRM(Speech Recognition Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	TCM(Transmission Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Antilock braking system module	Brake Fluid Change	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Calibration steering angle sensor	Pull Drift Compensation	Parameter Reset Clear Crash Data Memory	Parameter Reset/Configuration Emergency Assist Activation	Fuel Injector Correction Factors	DPF Static Regeneration	Reset the Oil Change Indicator	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the Air Conditioning Compressor Learned Values	Reset the Exhaust Gas Temperature Value	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Reset the Fuel Injection Pump Learned Values	Reset the Turbocharger Learned Values	Reset the Powertrain Control Module Learned Valus	Configure the lateral acceleration sensor	Configure the yaw rate sensor	Module initialization	Valve Calibration	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibrate Steering Angle Sensor(EPS)	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Module Confuguration	Key on engine run self test	Reset transmission table	Reset learned values	IVD Initialization Sequence	Module installation	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Ignition key erase	Ignition key programming
BETA-TEST	MONDEO-2.5L GASOLINE	TRM(Trailer Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	SYSTEM SEARCH																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	PCM(PowerTrain Control Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	ACM(Audio Control Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	CDP(Compact Disc Player)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	GDM(Generic Display Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	GEM(Generic Electronic Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	NAV(Navigation System)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	RCM(Restraint Control Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	RETM(Rear Entertainment Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	SRM(Speech Recognition Module)																																																	
BETA-TEST	F-150 5.4L	SYSTEM SEARCH																																																	
BETA-TEST	F-150 5.4L	PCM(PowerTrain Control Module)																																																	
BETA-TEST	F-150 5.4L	4X4(4x4 Control Module)																																																	
BETA-TEST	F-150 5.4L	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	F-150 5.4L	DSM(Driver Seat Module)																																																	
BETA-TEST	F-150 5.4L	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	F-150 5.4L	IC(Instrument Cluster)																																																	
BETA-TEST	F-150 5.4L	PAM(Parking Aid Module)																																																	
BETA-TEST	F-150 5.4L	RCM(Restraint Control Module)																																																	
BETA-TEST	F-150 5.4L	VSM(Vehicle Security Module)																																																	
BETA-TEST	F-150 5.4L	PATS(Passive Anti Theft System)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	SYSTEM SEARCH																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PCM(PowerTrain Control Module)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	ABS(Anti-Lock Brake System)																																											V						
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	IC(Instrument Cluster)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PAM(Parking Aid Module)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	RCM(Restraint Control Module)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	VSM(Vehicle Security Module)																																																	
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																	
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																	
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Confifure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
Incode Calculator	~2010.05	All model																																																		
ESCAPE	Up to 2004	SYSTEM SEARCH																																																		
ESCAPE	Up to 2004	PCM(PowerTrain Control Module)																																																		
ESCAPE	Up to 2004	Immobilizer																																																		
ESCAPE	Up to 2004	ABS(Anti-Lock Brake System)																																																		
ESCAPE	Up to 2004	RCM(Restraint Control Module)																																																		
ESCAPE	Up to 2004	GEM(Generic Electronic Module)																																																		
ESCAPE	From 2004	SYSTEM SEARCH																																																		
ESCAPE	From 2004	PCM(PowerTrain Control Module)																																																		
ESCAPE	From 2004	PATS(Passive anti theft system)																																																		
ESCAPE	From 2004	ABS(Anti-Lock Brake System)																																																		
ESCAPE	From 2004	ABS(Anti-Lock Brake System)																																																		
ESCAPE	From 2004	RCM(Restraint Control Module)																																																		
ESCAPE	From 2004	IC(Instrument Cluster)																																																		
ESCAPE	From 2004	GEM(Generic Electronic Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	SYSTEM SEARCH																																																	
EXPLORER	2011 MY	3.5L TiCVT	PCM(Powertrain Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2011 MY	3.5L TiCVT	ACM(Audio Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	BCM(Body Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	ATCM(All Terrain Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	C-CM(Cruise Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	CLM(Column Lock Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	DCSM(Driver-Dual Climate Contol Seat Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	DSM(Driver Seat Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	DSP(Digital Signal Processing Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	FCIM(Front Controls Interface Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	FCDIM(Front Control/Display Interface Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	FLM(Front Lighting Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	GPSM(Global Positioning System Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	HUD(Head Up Display)																																																	
EXPLORER	2011 MY	3.5L TiCVT	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER	2011 MY	3.5L TiCVT	IPC(Instrument Panel Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	LTM(Liftgate/Trunk Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	PAM(Parking Aid Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	PSCM(Power Steering Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	RCM(Restraint Control Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	RFA(Remote Function Actuator)																																																	
EXPLORER	2011 MY	3.5L TiCVT	RLCM-A(Rear Lighting Control Module A)																																																	
EXPLORER	2011 MY	3.5L TiCVT	SCCM(Streering Colume Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
EXPLORER	2011 MY	3.5L TiCVT	SOD-L(Side Obstacle Detection Control Module Left)																																																	
EXPLORER	2011 MY	3.5L TiCVT	SOD-R(Side Obstacle Detection Control Module Right)																																																	
EXPLORER	2011 MY	3.5L TiCVT	TPM(Tire Pressure Monitor)																																																	
EXPLORER	2010 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2010 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2010 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER	2010 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2010 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER	2010 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER	2010 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2010 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER	2010 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER	2010 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2009 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2009 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2009 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER	2009 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2009 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER	2009 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER	2009 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2009 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER	2009 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER	2009 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2008 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2008 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2008 MY	4.6L	TCM(Transmission Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
EXPLORER	2008 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER	2008 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2008 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER	2008 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER	2008 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER	2008 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER	2008 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2008 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER	2008 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER	2008 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2008 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2007 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2007 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2007 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER	2007 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER	2007 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2007 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER	2007 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER	2007 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER	2007 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER	2007 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2007 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER	2007 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER	2007 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2007 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2006 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2006 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2006 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER	2006 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER	2006 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2006 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER	2006 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER	2006 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER	2006 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER	2006 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2006 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER	2006 MY	4.6L	PRB(Power Running Board)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
EXPLORER	2006 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2006 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2000 MY	SYSTEM SEARCH																																																		
EXPLORER	2000 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	2000 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	2000 MY	RCM(Restraint Control Module)																																																		
EXPLORER	2000 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER	2000 MY	GEM(Generic Electronic Module)																																																		
EXPLORER	2000 MY	PAM(Parking Aid Module)																																																		
EXPLORER	1999 MY	SYSTEM SEARCH																																																		
EXPLORER	1999 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	1999 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	1999 MY	RCM(Restraint Control Module)																																																		
EXPLORER	1999 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER	1999 MY	PAM(Parking Aid Module)																																																		
EXPLORER	1998 MY	SYSTEM SEARCH																																																		
EXPLORER	1998 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	1998 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	1998 MY	RCM(Restraint Control Module)																																																		
EXPLORER	1998 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER	1997 MY	SYSTEM SEARCH																																																		
EXPLORER	1997 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	1997 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	1997 MY	RCM(Restraint Control Module)																																																		
EXPLORER	1997 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	RCM(Restraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Configure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
EXPLORER SPORT-TRAC	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
EXPLORER SPORT-TRAC	2007 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	BCM(Body Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	GPSM(Global Positioning System Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
ECOSPORT	1.5L	DURATEC VCT	SYSTEM SEARCH																																																	
ECOSPORT	1.5L	DURATEC VCT	PCM(Powertrain Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	ABS(Anti-Lock Brake System)																																																	
ECOSPORT	1.5L	DURATEC VCT	ACM(Audio Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	BCMii(Body Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	GPSM(Global Positioning System Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																	
ECOSPORT	1.5L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	PSCM(Power Steering Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	RCM(Restraint Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	RFA(Remote Function Actuator)																																																	
ECOSPORT	1.5L	DURATEC VCT	TCM(Transmission Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	SYSTEM SEARCH																																																	
FIESTA	1.25L	DURATEC 16V	PCM(PowerTrain Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.25L	DURATEC 16V	ACM(Audio Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	APIM(Accessory Protocol Interface Module)																																																	
FIESTA	1.25L	DURATEC 16V	BCMii(Body Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	DDM(Driver's Door Module)																																																	
FIESTA	1.25L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.25L	DURATEC 16V	FDSM(Front Distance Sensing Module)																																																	
FIESTA	1.25L	DURATEC 16V	GPSM(Global Positioning System Module)																																																	
FIESTA	1.25L	DURATEC 16V	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.25L	DURATEC 16V	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	PDM(Passenger's Door Module)																																																	
FIESTA	1.25L	DURATEC 16V	PSCM(Power Steering Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	RCM(Restraint Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	RFA(Remote Function Actuator)																																																	
FIESTA	1.4L GASOLINE	SYSTEM SEARCH																																																		
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Configure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)																																																		
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)																																																		
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.4L GASOLINE	APIM(Accessory Protocol Interface Module)																																																		
FIESTA	1.4L GASOLINE	PSCM(Power Steering Control Module)																																																		
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)																																																		
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)																																																		
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.4L GASOLINE	GEM(Generic Electronic Module)																																																		
FIESTA	1.4L GASOLINE	BCMii(Body Control Module)																																																		
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
FIESTA	1.4L GASOLINE	RFA(Remote Function Actuator)																																																		
FIESTA	1.4L GASOLINE	SRM(Speech Recognition Module)																																																		
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)																																																		
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)																																																		
FIESTA	1.4L GASOLINE	DDM(Driver's Door Module)																																																		
FIESTA	1.4L GASOLINE	FDSM(Front Distance Sensing Module)																																																		
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.4L GASOLINE	GPSM(Global Positioning System Module)																																																		
FIESTA	1.4L GASOLINE	PDM(Passenger's Door Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)		V	V	V																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)					V	V																																											
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)							V	V																																										
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)					V	V																																											
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.5L	TiVCT	SYSTEM SEARCH																																																	
FIESTA	1.5L	TiVCT	PCM(PowerTrain Control Module)																																																	
FIESTA	1.5L	TiVCT	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.5L	TiVCT	ACM(Audio Control Module)																																																	
FIESTA	1.5L	TiVCT	BCMii(Body Control Module)																																																	
FIESTA	1.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.5L	TiVCT	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.5L	TiVCT	PSCM(Power Steering Control Module)																																																	
FIESTA	1.5L	TiVCT	RCM(Retraint Control Module)					V	V																																											
FIESTA	1.5L	TiVCT	RFA(Remote Function Actuator)																																																	
FIESTA	1.5L	TiVCT	SRM(Speech Recognition Module)																																																	
FIESTA	1.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.5L	TiVCT	TCM(Transmission Control Module)																																																	
FIESTA	1.6L GASOLINE	SYSTEM SEARCH																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)																																																		
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)																																																		
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.6L GASOLINE	PSCM(Power Steering Control Module)																																																		
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)																																																		
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)																																																		
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)																																																		
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)																																																		
FIESTA	1.6L GASOLINE	BCMii(Body Control Module)																																																		
FIESTA	1.6L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)																																																		
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)																																																		
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)																																																		
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)																																																		
FIESTA	1.6L ZETEC ROCAM	SYSTEM SEARCH																																																		
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)																																																		
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)																																																		
FIESTA	1.6L ZETEC ROCAM	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.6L ZETEC ROCAM	IC(Instrument Cluster)																																																		
FIESTA	1.6L ZETEC ROCAM	RCM(Restraint Control Module)																																																		
FIESTA	1.6L ZETEC ROCAM	RKE(Remote Keyless Entry)																																																		
FIESTA	1.6L ZETEC ROCAM	TCM(Transmission Control Module)																																																		
FIESTA	1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																																		
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																		
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																		
FIESTA	1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																																																		
FIESTA	1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																																																		
FIESTA	2.0L GASOLINE	SYSTEM SEARCH																																																		
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	2.0L GASOLINE	ACM(Audio Control Module)																																																		
FIESTA	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FIESTA	2.0L GASOLINE	GEM(Generic Electronic Module)																																																		
FIESTA	2.0L GASOLINE	IC(Instrument Cluster)																																																		
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)																																																		
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)																																																		
FIESTA	2.0L GASOLINE	RCM(Restraint Control Module)																																																		
FIESTA	2.0L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																		
FIGO	1.4L DIESEL	SYSTEM SEARCH																																																		
FIGO	1.4L DIESEL	PCM(Powertrain Control Module)										V	V																																							
FIGO	1.4L DIESEL	ABS(Anti-Lock Brake System)																																																		
FIGO	1.4L DIESEL	IC(Instrument Cluster)												V	V																																					
FIGO	1.4L DIESEL	RCM(Restraint Control Module)																																																		
FIGO	1.6L	DURATEC 16V	SYSTEM SEARCH																																																	
FIGO	1.6L	DURATEC 16V	PCM(Powertrain Control Module)																																																	
FIGO	1.6L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																	
FIGO	1.6L	DURATEC 16V	GEM(Generic Electronic Module)																																																	
FIGO	1.6L	DURATEC 16V	IC(Instrument Cluster)											V	V																																					
FIGO	1.6L	DURATEC 16V	RCM(Restraint Control Module)																																																	
FIGO	1.6L	DURATEC 16V	TCM(Transmission Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM(Front Distance Sensing Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)													V																																				
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																	
FOCUS	1.4L	DURATEC 16V	SYSTEM SEARCH																																																	
FOCUS	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)														V	V	V	V	V	V																															
FOCUS	1.4L	DURATEC 16V	ACM(Audio Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	CDP(Compact Disc Player)																																																	
FOCUS	1.4L	DURATEC 16V	D_DCU(Driver Door Control Unit)																				V																														
FOCUS	1.4L	DURATEC 16V	GDM(Generic Display Module)																																																	
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																																																	
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																				V																														
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	1.4L	DURATEC 16V	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS	1.4L	DURATEC 16V	IC(Instrument Cluster)																																																	
FOCUS	1.4L	DURATEC 16V	NAV(Navigation System)																																																	
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)																																																	
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)																																																	
FOCUS	1.4L	DURATEC 16V	PDM(Passenger's Door Module)																				V																														
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	RKE(Remote Keyless Entry)																																																	
FOCUS	1.4L	DURATEC 16V	CSM(Central Security Module)																																																	
FOCUS	1.4L	DURATEC 16V	HEC(Hybrid Electrical Cluster)																																																	
FOCUS	1.4L	DURATEC 16V	MC(Message Center)																																																	
FOCUS	1.4L	DURATEC 16V	RETM(Rear Entertainment Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)				V																	V	V	V	V	V	V	V																							
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TCM(Transmission Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)																												V	V																					
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body control module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	CCMii(Cruise Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	DDM(Driver's Door Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	DDM(Driver's Door Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FCIM(Front Controls Interface Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FDSM(Front Distance Sensing Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	GPSM(Global Positioning System Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	HCM(Headlamp Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	HVAC(Heating Ventilation Air Conditioning)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	IPM-A(Image Processing Module A)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	IPC(Instrument Panel Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PAM(Parking Aid Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PDM(Passenger's Door Module)																														V	V																			
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PSCM(Power Steering Control Module)																																V	V																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	RCM(Restraint Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	RFA(Remote Function Actuator)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SASM(Steering Angle Sensor Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	TRM(Trailer Module)																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	SYSTEM SEARCH																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	PCM(PowerTrain Control Module)																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	GEM(Generic Electronic Module)																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	RCM(Restraint Control Module)																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	MC(Message Center)																																																	
FOCUS	1.6L GASOLINE	DURATEC	SYSTEM SEARCH																																																	
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)														V	V	V	V	V	V																															
FOCUS	1.6L GASOLINE	DURATEC	ACM(Audio Control Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	CDP(Compact Disc Player)																																																	
FOCUS	1.6L GASOLINE	DURATEC	D_DCU(Driver Door Control Unit)																				V																														
FOCUS	1.6L GASOLINE	DURATEC	GDM(Generic Display Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)																				V																														
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	1.6L GASOLINE	DURATEC	FFH(Fuel Fired Coolant Heating Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure/Refit the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FOCUS	1.6L GASOLINE	DURATEC	IC(Instrument Cluster)																																																
FOCUS	1.6L GASOLINE	DURATEC	NAV(Navigation System)																																																
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	PDM(Passenger's Door Module)																				V																													
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	RKE(Remote Keyless Entry)																																																
FOCUS	1.6L GASOLINE	DURATEC	RL_DCU(Rear Left Door Control Unit)																																																
FOCUS	1.6L GASOLINE	DURATEC	RR_DCU(Rear Right Door Control Unit)																																																
FOCUS	1.6L GASOLINE	DURATEC	CSM(Central Security Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	HEC(Hybrid Electrical Cluster)																																																
FOCUS	1.6L GASOLINE	DURATEC	MC(Message Center)																																																
FOCUS	1.6L GASOLINE	DURATEC	PATS(Passive Anti Theft System)																																			V	V													
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SYSTEM SEARCH																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TCM(Transmission Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)														V	V	V	V	V	V																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																											V	V																					
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																				V													
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	APIM(Accessory Protocol Interface Module)																																					V	V											
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	BCMii(Body Control Module)																																							V									
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	CCMii(Cruise Control Module)																																								V								
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DDM(Driver's Door Module)																																									V	V						
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DSP(Digital Signal Processing Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCIM(Front Controls Interface Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FDSM(Front Distance Sensing Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HCM(Headlamp Control Module)																																											V					
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-A(Image Processing Module A)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-B(Image Processing Module B)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPC(Instrument Panel Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)																													V	V																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)																				V																													
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PSCM(Power Steering Control Module)																															V	V																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)																																											V					
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RFA(Remote Function Actuator)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SASM(Steering Angle Sensor Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SRM(Speech Recognition Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TRM(Trailer Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PATS(Passive Anti Theft System)																																													V	V			
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																															V	V	V
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)				V																	V																													
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)														V																																			
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																											V																						
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																				V																													
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GDM(Generic Display Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	NAV(Navigation System)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Condtioning)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)				V																	V																													
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																											V	V																					
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Condtioning)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																V	V																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)														V	V	V	V	V	V																														
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CMR(Camera Module Rear)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CDP(Compact Disc Player)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																				V																													
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPB(Electronic Parking Brake)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPS(Electronic Power Steering)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GDM(Generic Display Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)																				V																													
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HCM(Headlamp Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	IC(Instrument Cluster)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	NAV(Navigation System)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PDM(Passenger's Door Module)																				V																													
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CSM(Central Security Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	MC(Message Center)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																			V	V													
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SYSTEM SEARCH																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	TCM(Transmission Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)														V	V	V	V	V	V																														
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ACM(Audio Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CMR(Camera Module Rear)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CDP(Compact Disc Player)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CSM(Central Security Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																				V																													
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPB(Electronic Parking Brake)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPS(Electronic Power Steering)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GDM(Generic Display Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)																				V																													
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HCM(Headlamp Control Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	IC(Instrument Cluster)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	NAV(Navigation System)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PAM(Parking Aid Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PDM(Passenger's Door Module)																				V																														
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SRM(Speech Recognition Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																			V	V													
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SYSTEM SEARCH																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TCM(Transmission Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)														V	V	V	V	V	V																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																											V	V																					
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	AHCM(Auxiliary Heater Control Module)																																					V												
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	APIM(Accessory Protocol Interface Module)																																						V	V											
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	BCMii(Body Control Module)																																								V									
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	CCMii(Cruise Control Module)																																									V								
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DDM(Driver's Door Module)																																										V	V						
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DSP(Digital Signal Processing Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCIM(Front Controls Interface Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FDSM(Front Distance Sensing Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HCM(Headlamp Control Module)																																												V					
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-A(Image Processing Module A)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-B(Image Processing Module B)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPC(Instrument Panel Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)																														V	V																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)																				V																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Conffiture All Three sensros Togethers.	ESP Conffiture the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PSCM(Power Steering Control Module)																																V	V																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)																																										V						
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RFA(Remote Function Actuator)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SASM(Steering Angle Sensor Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SRM(Speech Recognition Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TRM(Trailer Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PATS(Passive Anti Theft System)																																											V	V				
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	SYSTEM SEARCH																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PCM(PowerTrain Control Module)																				V																											V	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	TCM(Transmission Control Module)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ACM(Audio Control Module)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ABS(Anti-Lock Brake System)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CDP(Compact Disc Player)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CMR(Camera Module Rear)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	D_DCU(Driver Door Control Unit)																			V																													
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	EATC(Electronic Automatic Temperature Control)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	EPS(Electronic Power Steering)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FACM(Fuel Additive Control Module)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FFH(Fuel Fired Coolant Heating Module)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	GEM(Generic Electronic Module)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	HCM(Headlamp Control Module)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	IC(Instrument Cluster)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PDM(Passenger's Door Module)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PAM(Parking Aid Module)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RCM(Restraint Control Module)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RETM(Rear Entertainment Module)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RKE(Remote Keyless Entry)																																															
FOCUS	2.5L GASOLINE	SYSTEM SEARCH																																																	
FOCUS	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
FOCUS	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
FOCUS	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
FOCUS	2.5L GASOLINE	EPS(Electronic Power Steering)																																																	
FOCUS	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
FOCUS	2.5L GASOLINE	GEM(Generic Electronic Module)																																																	
FOCUS	2.5L GASOLINE	IC(Instrument Cluster)																																																	
FOCUS	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
FOCUS	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
FOCUS	2.5L GASOLINE	MC(Message Center)																																																	
FOCUS	2.5L GASOLINE	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FOCUS C-MAX	1.6L DIESEL	SYSTEM SEARCH																																																	
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)																																															V	V	V
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)					V																	V																											
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)														V																																			
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)																												V																					
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	CDP(Compact Disc Player)																																																	
FOCUS C-MAX	1.6L DIESEL	CMR(Camera Module Rear)																																																	
FOCUS C-MAX	1.6L DIESEL	D_DCU(Driver Door Control Unit)																					V																													
FOCUS C-MAX	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS C-MAX	1.6L DIESEL	EPS(Electronic Power Steering)																																																	
FOCUS C-MAX	1.6L DIESEL	FACM(Fuel Additive Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS C-MAX	1.6L DIESEL	GEM(Generic Electronic Module)																																																	
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	IC(Instrument Cluster)																																																	
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)																																																	
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)																																																	
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)																																																	
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)																																																	
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	RETM(Rear Entertainment Module)																																																	
FOCUS C-MAX	1.6L DIESEL	RKE(Remote Keyless Entry)																																																	
FOCUS C-MAX	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	BCMii(Body Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	DDM(Driver's Door Module)																																																	
FOCUS C-MAX	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS C-MAX	1.6L DIESEL	HVAC(Heating Ventilation Air Condtioning)																																																	
FOCUS C-MAX	1.6L DIESEL	IPM-A(Image Processing Module A)																																																	
FOCUS C-MAX	1.6L DIESEL	IPM-B(Image Processing Module B)																																																	
FOCUS C-MAX	1.6L DIESEL	IPC(Instrument Panel Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	PSCM(Power Steering Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	RFA(Remote Function Actuator)																																																	
FOCUS C-MAX	1.6L DIESEL	RGTM(Rear Gate/Trunk Module)																																																	
FOCUS C-MAX	1.6L DIESEL	SASM(Steering Angle Sensor Module)																																																	
FOCUS C-MAX	1.6L DIESEL	SRM(Speech Recognition Module)																																																	
FOCUS C-MAX	1.6L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS C-MAX	1.6L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS C-MAX	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FOCUS C-MAX	1.6L GASOLINE	SYSTEM SEARCH																																																	
FOCUS C-MAX	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																	
FOCUS C-MAX	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																	
FOCUS C-MAX	1.6L GASOLINE	ACM(Audio Control Module)																																																	
FOCUS C-MAX	1.6L GASOLINE	CDP(Compact Disc Player)																																																	
FOCUS C-MAX	1.6L GASOLINE	CMR(Camera Module Rear)																																																	
FOCUS C-MAX	1.6L GASOLINE	D_DCU(Driver Door Control Unit)																					V																													
FOCUS C-MAX	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS C-MAX	1.6L GASOLINE	EPS(Electronic Power Steering)																																																	
FOCUS C-MAX	1.6L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS C-MAX	1.6L GASOLINE	GEM(Generic Electronic Module)																					V																													
FOCUS C-MAX	1.6L GASOLINE	HCM(Headlamp Control Module)																																																	
FOCUS C-MAX	1.6L GASOLINE	IC(Instrument Cluster)																																																	
FOCUS C-MAX	1.6L GASOLINE	PAM(Parking Aid Module)																																																	
FOCUS C-MAX	1.6L GASOLINE	PDM(Passenger's Door Module)																																																	
FOCUS C-MAX	1.6L GASOLINE	RCM(Restraint Control Module)																																																	
FOCUS C-MAX	1.6L GASOLINE	RETM(Rear Entertainment Module)																																																	
FOCUS C-MAX	1.6L GASOLINE	RKE(Remote Keyless Entry)																																																	
FOCUS C-MAX	1.6L GASOLINE	GDM(Generic Display Module)																																																	
FOCUS C-MAX	1.6L GASOLINE	NAV(Navigation System)																																																	
FOCUS C-MAX	1.6L GASOLINE	RL_DCU(Rear Left Door Control Unit)																																																	
FOCUS C-MAX	1.6L GASOLINE	RR_DCU(Rear Right Door Control Unit)																																																	
FOCUS C-MAX	1.6L GASOLINE	SRM(Speech Recognition Module)																																																	
FOCUS C-MAX	1.6L GASOLINE	TCM(Transmission Control Module)																																																	
FOCUS C-MAX	1.8L GASOLINE	SYSTEM SEARCH																																																	
FOCUS C-MAX	1.8L GASOLINE	PCM(PowerTrain Control Module)																																																	
FOCUS C-MAX	1.8L GASOLINE	ABS(Anti-Lock Brake System)															V	V	V	V	V	V																														
FOCUS C-MAX	1.8L GASOLINE	ACM(Audio Control Module)																																																	
FOCUS C-MAX	1.8L GASOLINE	CMR(Camera Module Rear)																																																	
FOCUS C-MAX	1.8L GASOLINE	CDP(Compact Disc Player)																																																	
FOCUS C-MAX	1.8L GASOLINE	D_DCU(Driver Door Control Unit)																					V																													
FOCUS C-MAX	1.8L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS C-MAX	1.8L GASOLINE	EPB(Electronic Parking Brake)																																																	
FOCUS C-MAX	1.8L GASOLINE	EPS(Electronic Power Steering)																																																	
FOCUS C-MAX	1.8L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS C-MAX	1.8L GASOLINE	GDM(Generic Display Module)																																																	
FOCUS C-MAX	1.8L GASOLINE	GEM(Generic Electronic Module)																					V																													
FOCUS C-MAX	1.8L GASOLINE	HCM(Headlamp Control Module)																																																	
FOCUS C-MAX	1.8L GASOLINE	IC(Instrument Cluster)																																																	
FOCUS C-MAX	1.8L GASOLINE	NAV(Navigation System)																																																	
FOCUS C-MAX	1.8L GASOLINE	PAM(Parking Aid Module)																																																	
FOCUS C-MAX	1.8L GASOLINE	PDM(Passenger's Door Module)																					V																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FOCUS C-MAX	1.8L GASOLINE	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	RETM(Rear Entertainment Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	RKE(Remote Keyless Entry)																																																		
FOCUS C-MAX	1.8L GASOLINE	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SYSTEM SEARCH																																																		
FOCUS C-MAX	2.0L DIESEL	PCM(PowerTrain Control Module)				V	V				V																																										
FOCUS C-MAX	2.0L DIESEL	ABS(Anti-Lock Brake System)																												V																							
FOCUS C-MAX	2.0L DIESEL	ACM(Audio Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																						V												
FOCUS C-MAX	2.0L DIESEL	BCMii(Body Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	DDM(Driver's Door Module)																																											V							
FOCUS C-MAX	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																																																		
FOCUS C-MAX	2.0L DIESEL	HCM(Headlamp Control Module)																																												V						
FOCUS C-MAX	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
FOCUS C-MAX	2.0L DIESEL	IPM-A(Image Processing Module A)																																																		
FOCUS C-MAX	2.0L DIESEL	IPM-B(Image Processing Module B)																																																		
FOCUS C-MAX	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	2.0L DIESEL	PDM(Passenger's Door Module)																																V																		
FOCUS C-MAX	2.0L DIESEL	PSCM(Power Steering Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	RCM(Restraint Control Module)														V																																				
FOCUS C-MAX	2.0L DIESEL	RFA(Remote Function Actuator)																																																		
FOCUS C-MAX	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																		
FOCUS C-MAX	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																		
FOCUS C-MAX	2.0L GASOLINE	SYSTEM SEARCH																																																		
FOCUS C-MAX	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	ABS(Anti-Lock Brake System)															V	V	V	V	V	V																														
FOCUS C-MAX	2.0L GASOLINE	ACM(Audio Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	CDP(Compact Disc Player)																																																		
FOCUS C-MAX	2.0L GASOLINE	CMR(Camera Module Rear)																																																		
FOCUS C-MAX	2.0L GASOLINE	D_DCU(Driver Door Control Unit)																					V																														
FOCUS C-MAX	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS C-MAX	2.0L GASOLINE	EPB(Electronic Parking Brake)																																																		
FOCUS C-MAX	2.0L GASOLINE	EPS(Electronic Power Steering)																																																		
FOCUS C-MAX	2.0L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	GDM(Generic Display Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	GEM(Generic Electronic Module)																					V																														
FOCUS C-MAX	2.0L GASOLINE	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	IC(Instrument Cluster)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
FOCUS C-MAX	2.0L GASOLINE	NAV(Navigation System)																																																	
FOCUS C-MAX	2.0L GASOLINE	PAM(Parking Aid Module)																																																	
FOCUS C-MAX	2.0L GASOLINE	PDM(Passenger's Door Module)																					V																													
FOCUS C-MAX	2.0L GASOLINE	RCM(Restraint Control Module)																																																	
FOCUS C-MAX	2.0L GASOLINE	RETM(Rear Entertainment Module)																																																	
FOCUS C-MAX	2.0L GASOLINE	RKE(Remote Keyless Entry)																																																	
FOCUS C-MAX	2.0L GASOLINE	SRM(Speech Recognition Module)																																																	
FUSION	1.4L DIESEL	SYSTEM SEARCH																																																	
FUSION	1.4L DIESEL	PCM(PowerTrain Control Module)																																																	
FUSION	1.4L DIESEL	TCM(Transmission Control Module)																																																	
FUSION	1.4L DIESEL	ABS(Anti-Lock Brake System)																																																	
FUSION	1.4L DIESEL	IC(Instrument Cluster)																																																	
FUSION	1.4L DIESEL	ACM(Audio Control Module)																																																	
FUSION	1.4L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
FUSION	1.4L DIESEL	GEM(Generic Electronic Module)																																																	
FUSION	1.4L DIESEL	SRM(Speech Recognition Module)																																																	
FUSION	1.4L DIESEL	RCM(Restraint Control Module)																																																	
FUSION	1.4L DIESEL	PATS(Passive Anti Theft System)-BETA																																																	
FUSION	1.6L DIESEL	SYSTEM SEARCH																																																	
FUSION	1.6L DIESEL	PCM(PowerTrain Control Module)																																																	
FUSION	1.6L DIESEL	TCM(Transmission Control Module)																																																	
FUSION	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																	
FUSION	1.6L DIESEL	IC(Instrument Cluster)																																																	
FUSION	1.6L DIESEL	ACM(Audio Control Module)																																																	
FUSION	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
FUSION	1.6L DIESEL	GEM(Generic Electronic Module)																																																	
FUSION	1.6L DIESEL	SRM(Speech Recognition Module)																																																	
FUSION	1.6L DIESEL	RCM(Restraint Control Module)																																																	
FUSION	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																												V																					
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																					V											
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)													V																																				
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)				V																	V																														
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																												V																						
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																					V													
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)													V																																				
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)				V																V	V																											
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																											V																					
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																			V													
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)													V																																			
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																											V																					
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																			V													
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Conffiure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)													V																																				
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)		V	V	V																																													
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																												V																						
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																					V												
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)													V																																				
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)		V	V	V																																														
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TCM(Transmission Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																												V																							
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																				V														
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CDP(Compact Disc Player)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DABM(Digital Audio Broadcast Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver's Seat Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	NAV(Navigation System)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)													V																																				
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																					V	V												
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																																																	
F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																																																	
F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																																																	
F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																																																	
F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																																							V	V									
F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																																																	
F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																																																	
F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																																																	
F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																																																	
F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																																																	
F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																																																	
F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																																																	
F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																																																	
F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																																																	
F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																																																	
F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																																																	
F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																																																	
F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																																																	
F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																																																	
F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																																																	
F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																																																	
F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																																																	
F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiture the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																																																
F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																																																
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																																																
F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																																																
F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																																																
F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																																																
F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																																																
F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																																																
F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																																																
F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																																																
F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																																																
F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																																																
F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																																																
F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																																																
F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																																																
F150	4.6L(BETA)	3V	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Configure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																																																	
F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																																																	
F150	4.6L(BETA)	3V	ACM(Audio Control Module)																																																	
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																																																	
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																																																	
F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																																																	
F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																																																	
F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																																																	
F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																																																	
F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																																																	
F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																																																	
F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	4.6L(BETA)	3V	IC(Instrument Cluster)																																																	
F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																																																	
F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																																																	
F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																																																	
F150	4.6L(BETA)	3V	PRB(Power Running Board)																																																	
F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																																																	
F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																																																	
F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																																																	
F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																																																	
F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																																																	
F150	5.0L	TiVCT	SYSTEM SEARCH																																																	
F150	5.0L	TiVCT	PCM(Powertrain Control Module)																																																	
F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																																																	
F150	5.0L	TiVCT	ACM(Audio Control Module)																																																	
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																																																	
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																																																	
F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																																																	
F150	5.0L	TiVCT	DSM(Driver's Seat Module)																																																	
F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																																																	
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																																																	
F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																																																	
F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																																																	
F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	5.0L	TiVCT	IC(Instrument Cluster)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiture the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																																																
F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																																																
F150	5.0L	TiVCT	PAM(Parking Aid Module)																																																
F150	5.0L	TiVCT	PAM(Parking Aid Module)																																																
F150	5.0L	TiVCT	PRB(Power Running Board)																																																
F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																																																
F150	5.0L	TiVCT	RCM(Restraint Control Module)																																																
F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																																																
F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																																																
F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																																																
F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																																																
F150	5.0L	TiVCT	TCM(Transmission Control Module)																																																
F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																																																
F150	5.4L	3V	2009 ~	SYSTEM SEARCH																																																
F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																																																
F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																																																
F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																																																
F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																																						V	V										
F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																																																
F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																																																
F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																																																
F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																																																
F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																																																
F150	5.4L	3V	2009 ~	GEMS/JB(Generic Electronic Module/Smart Junction Box)																																																
F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																																																
F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																																																
F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																																																
F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																																																
F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																																																
F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																																																
F150	5.4L	3V	2009 ~	PRB(Power Running Board)																																																
F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																																																
F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																																																
F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																																																
F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																																																
F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																																																
F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																																																
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																																																
F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																																																
F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																																																
F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																																																
F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																																
F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																																																
F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																																																
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																																																
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																																																
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																																																
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																																																
F150	6.2L(BETA)	2V	SYSTEM SEARCH																																																	
F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																																																	
F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																																																	
F150	6.2L(BETA)	2V	ACM(Audio Control Module)																																																	
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																																																	
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																																																	
F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																																																	
F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																																																	
F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																																																	
F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																																																	
F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																																																	
F150	6.2L(BETA)	2V	IC(Instrument Cluster)																																																	
F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																																																	
F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																																																	
F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																																																	
F150	6.2L(BETA)	2V	PRB(Power Running Board)																																																	
F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																																																	
F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																																																	
F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																																																	
F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																																																	
F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																																																	
F150	Other	2004 ~ 2008	SYSTEM SEARCH																																																	
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																																																	
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																																																	
F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																																																	
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																	
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																	
F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																																																	
F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																																																	
F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	Other	2004 ~ 2008	IC(Instrument Cluster)																																																	
F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																																																	
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																																																	
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																																																	
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																																																	
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																																																	
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																																																	
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																																																	
F250	7.3L	SYSTEM SEARCH																																																		
F250	7.3L	PCM(PowerTrain Control Module)																																																		
F250	7.3L	ABS(Anti-Lock Brake System)																																																		
F250	7.3L	ECS(Electronic Crash Sensor)																																																		
F250	7.3L	GEM(Generic Electronic Module)																																																		
F250	6.2L	SYSTEM SEARCH																																																		
F250	6.2L	PCM(Powertrain Control Module)																																																		
F250	6.2L	ABS(Anti-Lock Brake System)																																																		
F250	6.2L	ACM(Audio Control Module)																																																		
F250	6.2L	APIM(Accessory Protocol Interface Module)																																							V	V										
F250	6.2L	BCMii(Body Control Module)																																																		
F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																																																		
F250	6.2L	DSM(Driver Seat Module)																																																		
F250	6.2L	GPSM(Global Positioning System Module)																																																		
F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																																																		
F250	6.2L	IPC(Instrument Panel Control Module)																																																		
F250	6.2L	PAM(Parking Aid Module)																																																		
F250	6.2L	RCM(Restraint Control Module)																																																		
F250	6.2L	SCCM(Streering Colume Control Module)																																																		
F250	6.2L	TBC(Trailer Brake Control Module)																																																		
F250	6.2L	TCCM(Transfer Case Control Module)																																																		
F250	6.2L	TPM(Tire Pressure Monitor)																																																		
F250	6.0L Diesel	SYSTEM SEARCH																																																		
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																		
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																		
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																		
F250	6.0L Diesel	ABS(Anti-Lock Brake System)																																																		
F250	6.0L Diesel	GEM(Generic Electronic Module)																																																		
F250	6.0L Diesel	HEC(Hybrid Electrical Cluster)																																																		
F250	6.0L Diesel	OTC(Overhead Trip Computer)																																																		
F250	6.0L Diesel	PAM(Parking Aid Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Conffiture All Three sensros Togethers.	ESP Conffiture the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
F250	6.0L Diesel	PATS(Passive Anti Theft System)																																																		
F250	6.0L Diesel	RCM(Restraint Control Module)																																																		
F250	6.0L Diesel	TCM(Transmission Control Module)																																																		
F250	6.0L Diesel	TCM(Transmission Control Module)																																																		
F250	6.0L Diesel	TCM(Transmission Control Module)																																																		
F250	6.0L Diesel	VSM(Vehicle Security Module)																																																		
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Conifiure All Three sensros Togethers.	ESP Conifiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																																						V									
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																																															
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																
KA	KA	SYSTEM SEARCH																																																	
KA	KA	PCM(PowerTrain Control Module)																																																	
KA	KA	ABS(Anti-Lock Brake System)																																																	
KA	KA	RCM(Restraint Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																
KUGA	2.0L DIESEL	SYSTEM SEARCH																																																	
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)			V						V																																								V	
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)					V																	V	V																											
KUGA	2.0L DIESEL	TCM(Transmission Control Module)																																																	
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)															V	V	V	V	V	V																														
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
KUGA	2.0L DIESEL	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
KUGA	2.0L DIESEL	ACM(Audio Control Module)																																																		
KUGA	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
KUGA	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																																																		
KUGA	2.0L DIESEL	AWD(All Wheel Drive Module)																																																		
KUGA	2.0L DIESEL	BCMii(Body Control Module)																																																		
KUGA	2.0L DIESEL	CCMii(Cruise Control Module)																																																		
KUGA	2.0L DIESEL	CMR(Camera Module Rear)																																																		
KUGA	2.0L DIESEL	D_DCU(Driver Door Control Unit)																					V																														
KUGA	2.0L DIESEL	DDM(Driver's Door Module)																																																		
KUGA	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																		
KUGA	2.0L DIESEL	EPS(Electronic Power Steering)																																																		
KUGA	2.0L DIESEL	FDSM(Front Distance Sensing Module)																																																		
KUGA	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																																																		
KUGA	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																		
KUGA	2.0L DIESEL	GEM(Generic Electronic Module)																																																		
KUGA	2.0L DIESEL	GPSM(Global Positioning System Module)																																																		
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)																																																		
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)																																																		
KUGA	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
KUGA	2.0L DIESEL	IPM-A(Image Processing Module A)																																																		
KUGA	2.0L DIESEL	IPM-B(Image Processing Module B)																																																		
KUGA	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																		
KUGA	2.0L DIESEL	IC(Instrument Cluster)																																																		
KUGA	2.0L DIESEL	PAM(Parking Aid Module)																																																		
KUGA	2.0L DIESEL	PAM(Parking Aid Module)																																																		
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)																																																		
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)																																																		
KUGA	2.0L DIESEL	PSCM(Power Steering Control Module)																																																		
KUGA	2.0L DIESEL	RCM(Restraint Control Module)																																																		
KUGA	2.0L DIESEL	RCM(Restraint Control Module)																																																		
KUGA	2.0L DIESEL	RFA(Remote Function Actuator)																																																		
KUGA	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																		
KUGA	2.0L DIESEL	RETM(Rear Entertainment Module)																																																		
KUGA	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																		
KUGA	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																		
KUGA	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																		
KUGA	2.0L DIESEL	SRM(Speech Recognition Module)																																																		
KUGA	2.0L DIESEL	TRM(Trailer Module)																																																		
KUGA	2.5L GASOLINE	SYSTEM SEARCH																																																		
KUGA	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																		
KUGA	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																		
KUGA	2.5L GASOLINE	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
KUGA	2.5L GASOLINE	AWD(All Wheel Drive Module)																																																	
KUGA	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
KUGA	2.5L GASOLINE	D_DCU(Driver Door Control Unit)																					V																													
KUGA	2.5L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
KUGA	2.5L GASOLINE	EPS(Electronic Power Steering)																																																	
KUGA	2.5L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																	
KUGA	2.5L GASOLINE	GEM(Generic Electronic Module)																																																	
KUGA	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
KUGA	2.5L GASOLINE	IC(Instrument Cluster)																																																	
KUGA	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
KUGA	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
KUGA	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
KUGA	2.5L GASOLINE	RETM(Rear Entertainment Module)																																																	
KUGA	2.5L GASOLINE	RKE(Remote Keyless Entry)																																																	
KUGA	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
KUGA	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										V																							
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																			V													
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)												V																																				
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SDD-R(Side Obstacle Detection Control Module - Right)																																															
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)																						V	V																								
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	CCMii(Cruise Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DCDC(DC to DC Convertal Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DDM(Driver's Door Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSM(Driver Seat Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSP(Digital Signal Processing Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCIM(Front Controls Interface Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FDSM(Front Distance Sensing Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCDIM(Front Control/Display Interface Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GPSM(Global Positioning System Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GWM(Gateway Module A)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HCM(Headlamp Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HSWM(Heated Steering Wheel Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HUD(Head Up Display)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPC(Instrument Panel Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PAM(Parking Aid Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PDM(Passenger's Door Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PSCM(Power Steering Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RACM(Rear Audio Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RCM(Restraint Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RGTM(Rear Gate/Trunk Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RTM(Radio Transceiver Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCCM(Streering Colume Control Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-E(Seat Control Module E)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-G(Seat Control Module G)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-H(Seat Control Module H)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SDD-L(Side Obstacle Detection Control Module Left)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SDD-R(Side Obstacle Detection Control Module Right)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TRM(Trailer Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)																							V	V																								
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DCDC(DC to DC Convertal Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver Seat Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSP(Digital Signal Processing Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GWM(Gateway Module A)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HSWM(Heated Steering Wheel Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HUD(Head Up Display)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RACM(Rear Audio Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RTM(Radio Transceiver Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCCM(Streering Colume Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-E(Seat Control Module E)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-G(Seat Control Module G)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-H(Seat Control Module H)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)			V																	V																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										V																							
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																		V															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)												V																																				
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										V																							
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																			V														
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)												V																																				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Together.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2012 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2012 MY	2.0L DIESEL	PCM(PowerTrain Control Module)				V																V	V																													
MONDEO	2012 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																											V																						
MONDEO	2012 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																			V														
MONDEO	2012 MY	2.0L DIESEL	BCMii(Body Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2012 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2012 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																
MONDEO	2012 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	2.0L DIESEL	IPM-A(Image Processing Module A)																																																
MONDEO	2012 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2012 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2012 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	RCM(Restraint Control Module)													V																																			
MONDEO	2012 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2012 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2012 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2012 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2012 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																
MONDEO	2012 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																
MONDEO	2012 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	TRM(Trailer Module)																																																
MONDEO	2012 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)			V																	V																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										V																						
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																		V														
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)												V																																				
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										V																							
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																			V														
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)												V																																				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2011 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2011 MY	2.0L DIESEL	PCM(PowerTrain Control Module)				V																V	V																													
MONDEO	2011 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																											V																						
MONDEO	2011 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																			V														
MONDEO	2011 MY	2.0L DIESEL	BCMii(Body Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																
MONDEO	2011 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	2.0L DIESEL	IPM-A(Image Processing Module A)																																																
MONDEO	2011 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	RCM(Restraint Control Module)													V																																			
MONDEO	2011 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2011 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2011 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2011 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2011 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																
MONDEO	2011 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																
MONDEO	2011 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	TRM(Trailer Module)																																																
MONDEO	2011 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2011 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																											V																						
MONDEO	2011 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2011 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																											V					
MONDEO	2011 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2011 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																													V			
MONDEO	2011 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2011 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2011 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2011 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																													V			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2010 MY	2.0L	DIESEL	SYSTEM SEARCH																																															
MONDEO	2010 MY	2.0L	DIESEL	PCM(PowerTrain Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	ABS(Anti-Lock Brake System)													V													V																					
MONDEO	2010 MY	2.0L	DIESEL	AHCM(Auxiliary Heater Control Module)																																			V												
MONDEO	2010 MY	2.0L	DIESEL	BCMii(Body Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	CCMii(Cruise Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	CMR(Camera Module Rear)																																															
MONDEO	2010 MY	2.0L	DIESEL	DDM(Driver's Door Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	DSM(Driver's Seat Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	HCM(Headlamp Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2010 MY	2.0L	DIESEL	IPC(Instrument Panel Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PAM(Parking Aid Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PBM(Parking Brake Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PDM(Passenger's Door Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PSCM(Power Steering Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	RCM(Restraint Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	RFA(Remote Function Actuator)																																															
MONDEO	2010 MY	2.0L	DIESEL	SASM(Steering Angle Sensor Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	SRM(Speech Recognition Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	TCM(Transmission Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	TRM(Trailer Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	VDM(Vehicle Dynamic Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										V																					
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																			V												
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)												V																																				
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2010 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																											V																							
MONDEO	2010 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2010 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																											V						
MONDEO	2010 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2010 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2010 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																	
MONDEO	2010 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																													V				
MONDEO	2010 MY	2.5L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2010 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2010 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2010 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2010 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2010 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2010 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																															V			
MONDEO	2009 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										V																								
MONDEO	2009 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																				V														
MONDEO	2009 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2009 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	2009 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)														V														V																				
MONDEO	2009 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																				V												
MONDEO	2009 MY	1.8L DIESEL	BCMii(Body Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																																
MONDEO	2009 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																											V					
MONDEO	2009 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	1.8L DIESEL	TRM(Trailer Module)																																																
MONDEO	2009 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2009 MY	2.0L DIESEL	SYSTEM SEARCH																																																
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)														V														V																				
MONDEO	2009 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																				V												
MONDEO	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																
MONDEO	2009 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2009 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	2.0L DIESEL	TRM(Trailer Module)																																																
MONDEO	2009 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2009 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																											V																					
MONDEO	2009 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																											V					
MONDEO	2009 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																												V				
MONDEO	2009 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2009 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2009 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Conffiure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2009 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2009 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																															V			
MONDEO	2008 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										V																							
MONDEO	2008 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																				V													
MONDEO	2008 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																	
MONDEO	2008 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	SYSTEM SEARCH																																																		
MONDEO	2008 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)														V													V																							
MONDEO	2008 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																					V													
MONDEO	2008 MY	1.8L DIESEL	BCMii(Body Control Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																		
MONDEO	2008 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2008 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																										V						
MONDEO	2008 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2008 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2008 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2008 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																																																
MONDEO	2008 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2008 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																
MONDEO	2008 MY	1.8L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2008 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2008 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2008 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2008 MY	1.8L DIESEL	TRM(Trailer Module)																																																
MONDEO	2008 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2008 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																											V																						
MONDEO	2008 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2008 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																										V						
MONDEO	2008 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2008 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2008 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																											V					
MONDEO	2008 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2008 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2008 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2008 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2008 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2008 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2008 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																															V			
MONDEO	2007 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										V																								
MONDEO	2007 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																				V														
MONDEO	2007 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure/Refit the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2007 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	2007 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)														V														V																				
MONDEO	2007 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																				V												
MONDEO	2007 MY	1.8L DIESEL	BCMii(Body Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2007 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2007 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																																
MONDEO	2007 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																												V					
MONDEO	2007 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2007 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2007 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2007 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2007 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2007 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2007 MY	1.8L DIESEL	TRM(Trailer Module)																																																
MONDEO	2007 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2007 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																												V																				
MONDEO	2007 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2007 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																												V					
MONDEO	2007 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2007 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2007 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2007 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																															V	
MONDEO	2007 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2007 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2007 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2007 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2007 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2007 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																															V	
MONDEO	2003 MY	2.0L DIESEL	SYSTEM SEARCH																																																
MONDEO	2003 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2003 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2003 MY	2.0L DIESEL	CSM(Central Security Module)																																																
MONDEO	2003 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																
MONDEO	2003 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																
MONDEO	2003 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																	
MONDEO	2003 MY	2.0L DIESEL	ACM(Audio Control Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	CDP(Compact Disc Player)																																																	
MONDEO	2003 MY	2.0L DIESEL	GDM(Generic Display Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	NAV(Navigation System)																																																	
MONDEO	2003 MY	2.0L DIESEL	RETM(Rear Entertainment Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	ICU(Injector Control Unit)																																																	
MONDEO	2003 MY	2.0L DIESEL	PATS(Passive Anti Theft System)																																																	
MONDEO	2002 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2002 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2002 MY	2.0L DIESEL	CSM(Central Security Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2002 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2002 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																	
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																	
MONDEO	2002 MY	2.0L DIESEL	ACM(Audio Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	CDP(Compact Disc Player)																																																	
MONDEO	2002 MY	2.0L DIESEL	GDM(Generic Display Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	NAV(Navigation System)																																																	
MONDEO	2002 MY	2.0L DIESEL	RETM(Rear Entertainment Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	ICU(Injector Control Unit)																																																	
MONDEO	2002 MY	2.0L DIESEL	PATS(Passive Anti Theft System)																																																	
MONDEO	2002 MY	2.0L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2002 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2002 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2002 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2002 MY	2.0L GASOLINE	GEM(Generic Electronic Module)																																																	
MONDEO	2002 MY	2.0L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2002 MY	2.0L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2001 MY	2.0L DIESEL	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Conifiure All Three sensros Togethers.	ESP Conifiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	2001 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2001 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2001 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
MONDEO	2001 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2001 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2001 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																	
MONDEO	2001 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2001 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																	
MONDEO	2001 MY	2.0L DIESEL	ACM(Audio Control Module)																																																	
MONDEO	2001 MY	2.0L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2001 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2001 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2001 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2001 MY	2.0L GASOLINE	GEM(Generic Electronic Module)																																																	
MONDEO	2001 MY	2.0L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2001 MY	2.0L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2000 MY	1.8L	SYSTEM SEARCH																																																	
MONDEO	2000 MY	1.8L	PCM(PowerTrain Control Module)																																																	
MONDEO	2000 MY	1.8L	ABS(Anti-Lock Brake System)																																																	
MONDEO	2000 MY	1.8L	CSM(Central Security Module)																																																	
MONDEO	2000 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2000 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	2000 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2000 MY	1.8L DIESEL	CSM(Central Security Module)																																																	
MONDEO	2000 MY	1.8L DIESEL	Passive Antitheft																																																	
MONDEO	2000 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																	
MONDEO	2000 MY	2.0L	SYSTEM SEARCH																																																	
MONDEO	2000 MY	2.0L	PCM(PowerTrain Control Module)																																																	
MONDEO	2000 MY	2.0L	ABS(Anti-Lock Brake System)																																																	
MONDEO	2000 MY	2.0L	CSM(Central Security Module)																																																	
MONDEO	2000 MY	2.5L	SYSTEM SEARCH																																																	
MONDEO	2000 MY	2.5L	PCM(PowerTrain Control Module)																																																	
MONDEO	2000 MY	2.5L	ABS(Anti-Lock Brake System)																																																	
MONDEO	2000 MY	2.5L	CSM(Central Security Module)																																																	
MONDEO	1999 MY	1.8L	SYSTEM SEARCH																																																	
MONDEO	1999 MY	1.8L	PCM(PowerTrain Control Module)																																																	
MONDEO	1999 MY	1.8L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1999 MY	1.8L	CSM(Central Security Module)																																																	
MONDEO	1999 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	1999 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MONDEO	1999 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	1999 MY	1.8L DIESEL	CSM(Central Security Module)																																																	
MONDEO	1999 MY	1.8L DIESEL	Passive Antitheft																																																	
MONDEO	1999 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																	
MONDEO	1999 MY	2.0L	SYSTEM SEARCH																																																	
MONDEO	1999 MY	2.0L	PCM(PowerTrain Control Module)																																																	
MONDEO	1999 MY	2.0L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1999 MY	2.0L	CSM(Central Security Module)																																																	
MONDEO	1999 MY	2.5L	SYSTEM SEARCH																																																	
MONDEO	1999 MY	2.5L	PCM(PowerTrain Control Module)																																																	
MONDEO	1999 MY	2.5L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1999 MY	2.5L	CSM(Central Security Module)																																																	
MONDEO	1998 MY	1.8L	SYSTEM SEARCH																																																	
MONDEO	1998 MY	1.8L	PCM(PowerTrain Control Module)																																																	
MONDEO	1998 MY	1.8L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1998 MY	1.8L	CSM(Central Security Module)																																																	
MONDEO	1998 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	1998 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	1998 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	1998 MY	1.8L DIESEL	CSM(Central Security Module)																																																	
MONDEO	1998 MY	1.8L DIESEL	Passive Antitheft																																																	
MONDEO	1998 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																	
MONDEO	1998 MY	2.0L	SYSTEM SEARCH																																																	
MONDEO	1998 MY	2.0L	PCM(PowerTrain Control Module)																																																	
MONDEO	1998 MY	2.0L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1998 MY	2.0L	CSM(Central Security Module)																																																	
MONDEO	1998 MY	2.5L	SYSTEM SEARCH																																																	
MONDEO	1998 MY	2.5L	PCM(PowerTrain Control Module)																																																	
MONDEO	1998 MY	2.5L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1998 MY	2.5L	CSM(Central Security Module)																																																	
MONDEO	1997 MY	1.8L	PCM(PowerTrain Control Module)																																																	
MONDEO	1997 MY	1.8L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1997 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	1997 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	1997 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	1997 MY	1.8L DIESEL	Passive Antitheft																																																	
MONDEO	1997 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																	
MONDEO	1997 MY	2.0L	PCM(PowerTrain Control Module)																																																	
MONDEO	1997 MY	2.0L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1997 MY	2.5L	PCM(PowerTrain Control Module)																																																	
MONDEO	1997 MY	2.5L	ABS(Anti-Lock Brake System)																																																	
MOUNTAINEER	2010 MY	4.6L	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Configure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MOUNTAINEER	2010 MY	4.6L	PCM(Powertrain Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	TCM(Transmission Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	4X4(4x4 Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
MOUNTAINEER	2010 MY	4.6L	ACM(Audio Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
MOUNTAINEER	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																	
MOUNTAINEER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
MOUNTAINEER	2010 MY	4.6L	DSM(Driver's Seat Module)																																																	
MOUNTAINEER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
MOUNTAINEER	2010 MY	4.6L	IC(Instrument Cluster)																																																	
MOUNTAINEER	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
MOUNTAINEER	2010 MY	4.6L	PAM(Parking Aid Module)																																																	
MOUNTAINEER	2010 MY	4.6L	PRB(Power Running Board)																																																	
MOUNTAINEER	2010 MY	4.6L	RCM(Restraint Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																	
MOUNTAINEER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
MOUNTAINEER	2009 MY	4.6L	SYSTEM SEARCH																																																	
MOUNTAINEER	2009 MY	4.6L	PCM(Powertrain Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	TCM(Transmission Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	4X4(4x4 Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
MOUNTAINEER	2009 MY	4.6L	ACM(Audio Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
MOUNTAINEER	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																	
MOUNTAINEER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
MOUNTAINEER	2009 MY	4.6L	DSM(Driver's Seat Module)																																																	
MOUNTAINEER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
MOUNTAINEER	2009 MY	4.6L	IC(Instrument Cluster)																																																	
MOUNTAINEER	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
MOUNTAINEER	2009 MY	4.6L	PAM(Parking Aid Module)																																																	
MOUNTAINEER	2009 MY	4.6L	PRB(Power Running Board)																																																	
MOUNTAINEER	2009 MY	4.6L	RCM(Restraint Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																	
MOUNTAINEER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
MUSTANG	4.0L V6 SOHC			SYSTEM SEARCH																																																
MUSTANG	4.0L V6 SOHC			PCM(Powertrain Control Module)																																																
MUSTANG	4.0L V6 SOHC			ABS(Anti-Lock Brake System)																																																
MUSTANG	4.0L V6 SOHC			ACM(Audio Control Module)																																																
MUSTANG	4.0L V6 SOHC			APIM(Accessory Protocol Interface Module)																																																
MUSTANG	4.0L V6 SOHC			GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
MUSTANG	4.0L V6 SOHC			RCM(Restraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
MUSTANG	4.0L V6 SOHC			SDARS(Satellite Digital Audio Receiver System)																																															
MUSTANG	4.0L V6 SOHC			IC(Instrument Cluster)																																															
TAURUS	2011 MY	3.5L	SYSTEM SEARCH																																																
TAURUS	2011 MY	3.5L	PCM(PowerTrain Control Module)																																																
TAURUS	2011 MY	3.5L	4X4(4x4 Control Module)																																																
TAURUS	2011 MY	3.5L	ABS(Anti-Lock Brake System)																																																
TAURUS	2011 MY	3.5L	ACM(Audio Control Module)																																																
TAURUS	2011 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																
TAURUS	2011 MY	3.5L	C-CM(Cruise Control Module)																																																
TAURUS	2011 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																
TAURUS	2011 MY	3.5L	DDM(Driver's Door Module)																																																
TAURUS	2011 MY	3.5L	DSM(Driver's Seat Module)																																																
TAURUS	2011 MY	3.5L	DSP(Digital Signal Processing Module)																																																
TAURUS	2011 MY	3.5L	FCIM(Front Controls Interface Module)																																																
TAURUS	2011 MY	3.5L	FDIM(Front Display Interface Module)																																																
TAURUS	2011 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
TAURUS	2011 MY	3.5L	GPSM(Global Positioning System Module)																																																
TAURUS	2011 MY	3.5L	HCM(Headlamp Control Module)																																																
TAURUS	2011 MY	3.5L	HCM-2(Headlamp Control Module2)																																																
TAURUS	2011 MY	3.5L	HUD(Head Up Display)																																																
TAURUS	2011 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																
TAURUS	2011 MY	3.5L	ILCM(Interior Lighting Control Module)																																																
TAURUS	2011 MY	3.5L	IPC(Instrument Panel Control Module)																																																
TAURUS	2011 MY	3.5L	OCSM(Occupant Classification System Module)																																																
TAURUS	2011 MY	3.5L	PAM(Parking Aid Module)																																																
TAURUS	2011 MY	3.5L	PSCM(Power Steering Control Module)																																																
TAURUS	2011 MY	3.5L	RCM(Restraint Control Module)																																																
TAURUS	2011 MY	3.5L	RETM(Rear Entertainment Module)																																																
TAURUS	2011 MY	3.5L	RFA(Remote Function Actuator)																																																
TAURUS	2011 MY	3.5L	SASM(Steering Angle Sensor Module)																																																
TAURUS	2011 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																
TAURUS	2011 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																
TAURUS	2010 MY	3.5L	SYSTEM SEARCH																																																
TAURUS	2010 MY	3.5L	PCM(PowerTrain Control Module)																																																
TAURUS	2010 MY	3.5L	4X4(4x4 Control Module)																																																
TAURUS	2010 MY	3.5L	ABS(Anti-Lock Brake System)																																																
TAURUS	2010 MY	3.5L	ACM(Audio Control Module)																																																
TAURUS	2010 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																
TAURUS	2010 MY	3.5L	C-CM(Cruise Control Module)																																																
TAURUS	2010 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																
TAURUS	2010 MY	3.5L	DDM(Driver's Door Module)																																																
TAURUS	2010 MY	3.5L	DSM(Driver's Seat Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Conffiure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
TAURUS	2010 MY	3.5L	DSP(Digital Signal Processing Module)																																																	
TAURUS	2010 MY	3.5L	FCIM(Front Controls Interface Module)																																																	
TAURUS	2010 MY	3.5L	FDIM(Front Display Interface Module)																																																	
TAURUS	2010 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
TAURUS	2010 MY	3.5L	GPSM(Global Positioning System Module)																																																	
TAURUS	2010 MY	3.5L	HCM(Headlamp Control Module)																																																	
TAURUS	2010 MY	3.5L	HCM-2(Headlamp Control Module2)																																																	
TAURUS	2010 MY	3.5L	HUD(Head Up Display)																																																	
TAURUS	2010 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																	
TAURUS	2010 MY	3.5L	ILCM(Interior Lighting Control Module)																																																	
TAURUS	2010 MY	3.5L	IPC(Instrument Panel Control Module)																																																	
TAURUS	2010 MY	3.5L	OCSM(Occupant Classification System Module)																																																	
TAURUS	2010 MY	3.5L	PAM(Parking Aid Module)																																																	
TAURUS	2010 MY	3.5L	PSCM(Power Steering Control Module)																																																	
TAURUS	2010 MY	3.5L	RCM(Restraint Control Module)																																																	
TAURUS	2010 MY	3.5L	RETM(Rear Entertainment Module)																																																	
TAURUS	2010 MY	3.5L	RFA(Remote Function Actuator)																																																	
TAURUS	2010 MY	3.5L	SASM(Steering Angle Sensor Module)																																																	
TAURUS	2010 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																	
TAURUS	2010 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																	
TAURUS	2009 MY	3.5L	SYSTEM SEARCH																																																	
TAURUS	2009 MY	3.5L	PCM(PowerTrain Control Module)																																																	
TAURUS	2009 MY	3.5L	4X4(4x4 Control Module)																																																	
TAURUS	2009 MY	3.5L	ABS(Anti-Lock Brake System)																																																	
TAURUS	2009 MY	3.5L	ACM(Audio Control Module)																																																	
TAURUS	2009 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																	
TAURUS	2009 MY	3.5L	C-CM(Cruise Control Module)																																																	
TAURUS	2009 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																	
TAURUS	2009 MY	3.5L	DDM(Driver's Door Module)																																																	
TAURUS	2009 MY	3.5L	DSM(Driver's Seat Module)																																																	
TAURUS	2009 MY	3.5L	DSP(Digital Signal Processing Module)																																																	
TAURUS	2009 MY	3.5L	FCIM(Front Controls Interface Module)																																																	
TAURUS	2009 MY	3.5L	FDIM(Front Display Interface Module)																																																	
TAURUS	2009 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
TAURUS	2009 MY	3.5L	GPSM(Global Positioning System Module)																																																	
TAURUS	2009 MY	3.5L	HCM(Headlamp Control Module)																																																	
TAURUS	2009 MY	3.5L	HCM-2(Headlamp Control Module2)																																																	
TAURUS	2009 MY	3.5L	HUD(Head Up Display)																																																	
TAURUS	2009 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																	
TAURUS	2009 MY	3.5L	ILCM(Interior Lighting Control Module)																																																	
TAURUS	2009 MY	3.5L	IPC(Instrument Panel Control Module)																																																	
TAURUS	2009 MY	3.5L	OCSM(Occupant Classification System Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
TAURUS	2009 MY	3.5L	PAM(Parking Aid Module)																																																	
TAURUS	2009 MY	3.5L	PSCM(Power Steering Control Module)																																																	
TAURUS	2009 MY	3.5L	RCM(Restraint Control Module)																																																	
TAURUS	2009 MY	3.5L	RETM(Rear Entertainment Module)																																																	
TAURUS	2009 MY	3.5L	RFA(Remote Function Actuator)																																																	
TAURUS	2009 MY	3.5L	SASM(Steering Angle Sensor Module)																																																	
TAURUS	2009 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																	
TAURUS	2009 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																	
TAURUS	2008 MY	3.5L	SYSTEM SEARCH																																																	
TAURUS	2008 MY	3.5L	PCM(PowerTrain Control Module)																																																	
TAURUS	2008 MY	3.5L	4X4(4x4 Control Module)																																																	
TAURUS	2008 MY	3.5L	ABS(Anti-Lock Brake System)																																																	
TAURUS	2008 MY	3.5L	ACM(Audio Control Module)																																																	
TAURUS	2008 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																	
TAURUS	2008 MY	3.5L	C-CM(Cruise Control Module)																																																	
TAURUS	2008 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																	
TAURUS	2008 MY	3.5L	DDM(Driver's Door Module)																																																	
TAURUS	2008 MY	3.5L	DSM(Driver's Seat Module)																																																	
TAURUS	2008 MY	3.5L	DSP(Digital Signal Processing Module)																																																	
TAURUS	2008 MY	3.5L	FCIM(Front Controls Interface Module)																																																	
TAURUS	2008 MY	3.5L	FDIM(Front Display Interface Module)																																																	
TAURUS	2008 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
TAURUS	2008 MY	3.5L	GPSM(Global Positioning System Module)																																																	
TAURUS	2008 MY	3.5L	HCM(Headlamp Control Module)																																																	
TAURUS	2008 MY	3.5L	HCM-2(Headlamp Control Module2)																																																	
TAURUS	2008 MY	3.5L	HUD(Head Up Display)																																																	
TAURUS	2008 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																	
TAURUS	2008 MY	3.5L	ILCM(Interior Lighting Control Module)																																																	
TAURUS	2008 MY	3.5L	IPC(Instrument Panel Control Module)																																																	
TAURUS	2008 MY	3.5L	OCSM(Occupant Classification System Module)																																																	
TAURUS	2008 MY	3.5L	PAM(Parking Aid Module)																																																	
TAURUS	2008 MY	3.5L	PSCM(Power Steering Control Module)																																																	
TAURUS	2008 MY	3.5L	RCM(Restraint Control Module)																																																	
TAURUS	2008 MY	3.5L	RETM(Rear Entertainment Module)																																																	
TAURUS	2008 MY	3.5L	RFA(Remote Function Actuator)																																																	
TAURUS	2008 MY	3.5L	SASM(Steering Angle Sensor Module)																																																	
TAURUS	2008 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																	
TAURUS	2008 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																	
TAURUS	1998 MY	SYSTEM SEARCH																																																		
TAURUS	1998 MY	PCM(PowerTrain Control Module)																																																		
TAURUS	1998 MY	ABS(Anti-Lock Brake System)																																																		
TAURUS	1998 MY	RCM(Restraint Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
TAURUS	1998 MY	RIM(Remote Immobilizer Module)																																																		
TAURUS	1997 MY	SYSTEM SEARCH																																																		
TAURUS	1997 MY	PCM(PowerTrain Control Module)																																																		
TAURUS	1997 MY	ABS(Anti-Lock Brake System)																																																		
TAURUS	1997 MY	RCM(Restraint Control Module)																																																		
TAURUS	1997 MY	RIM(Remote Immobilizer Module)																																																		
TAURUS	1996 MY	SYSTEM SEARCH																																																		
TAURUS	1996 MY	PCM(PowerTrain Control Module)																																																		
TAURUS	1996 MY	ABS(Anti-Lock Brake System)																																																		
TAURUS	1996 MY	RCM(Restraint Control Module)																																																		
TAURUS	1996 MY	RIM(Remote Immobilizer Module)																																																		
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	SYSTEM SEARCH																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PCM(PowerTrain Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	TCM(Transmission Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ABS(Anti-Lock Brake System)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ACM(Audio Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	APIM(Accessory Protocol Interface Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	BEM(Body Electronic Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	FCIM(Front Controls Interface Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GPSM(Global Positioning System Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GWM(Gateway Module A)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	HIM(HVAC Integrated Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	IPC(Instrument Panel Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PAM(Parking Aid Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PSCM(Power Steering Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	RCM(Restraint Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	SYSTEM SEARCH																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PCM(Powertrain Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	TCM(Transmission Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	ACM(Audio Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PSCM(Power Steering Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	HIM(HVAC Integrated Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
TERRITORY	2010~	4.0L GASOLINE	SY	FDIM(Front Display Interface Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	SYSTEM SEARCH																																																
TERRITORY	2010~	2.7L DIESEL	SZ	PCM(Powertrain Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	ABS(Anti-Lock Brake System)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	ACM(Audio Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	AWD(All Wheel Drive Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	BEM(Body Electronic Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	FDIM(Front Display Interface Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	HIM(HVAC Intergrated Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	IPC(Instrument Panel Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	PAM(Parking Aid Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	PSCM(Power Steering Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	RCM(Restraint Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	TCM(Transmission Control Module)																																																
TERRITORY	2009~2010	SYSTEM SEARCH																																																		
TERRITORY	2009~2010	PCM(PowerTrain Control Module)																																																		
TERRITORY	2009~2010	TCM(Transmission Control Module)																																																		
TERRITORY	2009~2010	ABS(Anti-Lock Brake System)																																																		
TERRITORY	2009~2010	RCM(Restraint Control Module)																																																		
TERRITORY	2009~2010	BEM(Body Electronic Module)																																																		
TERRITORY	2009~2010	IC(Instrument Cluster)																																																		
TERRITORY	2009~2010	HIM(HVAC Integrated Module)																																																		
TERRITORY	2009~2010	ACM(Audio Control Module)																																																		
TERRITORY	2005~2009	SYSTEM SEARCH																																																		
TERRITORY	2005~2009	PCM(PowerTrain Control Module)																																																		
TERRITORY	2005~2009	TCM(Transmission Control Module)																																																		
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)																																																		
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)																																																		
TERRITORY	2005~2009	RCM(Restraint Control Module)																																																		
TERRITORY	2005~2009	BEM(Body Electronic Module)																																																		
TERRITORY	2005~2009	IC(Instrument Cluster)																																																		
TERRITORY	2005~2009	HIM(HVAC Integrated Module)																																																		
TERRITORY	2005~2009	ACM(Audio Control Module)																																																		
TERRITORY	2004~2005	SYSTEM SEARCH																																																		
TERRITORY	2004~2005	PCM(PowerTrain Control Module)																																																		
TERRITORY	2004~2005	ABS(Anti-Lock Brake System)																																																		
TERRITORY	2004~2005	RCM(Restraint Control Module)																																																		
TERRITORY	2004~2005	BEM(Body Electronic Module)																																																		
TERRITORY	2004~2005	IC(Instrument Cluster)																																																		
TERRITORY	2004~2005	HIM(HVAC Integrated Module)																																																		
TERRITORY	2004~2005	HIM(HVAC Integrated Module)																																																		
TERRITORY	2004~2005	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
TERRITORY	2004~2005	PAM(Parking Aid Module)																																																	
TRANSIT	1.6L DIESEL	SYSTEM SEARCH																																																	
TRANSIT	1.6L DIESEL	PCM(PowerTrain Control Module)					V																																												
TRANSIT	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																	
TRANSIT	1.6L DIESEL	ACM(Audio Control Module)																																																	
TRANSIT	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
TRANSIT	1.6L DIESEL	APIM(Accessory Protocol Interface Module)																																																	
TRANSIT	1.6L DIESEL	BCMii(Body Control Module)																																																	
TRANSIT	1.6L DIESEL	DDM(Driver's Door Module)																																																	
TRANSIT	1.6L DIESEL	FCIM(Front Controls Interface Module)																																																	
TRANSIT	1.6L DIESEL	FDSM(Front Distance Sensing Module)																																																	
TRANSIT	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)																																																	
TRANSIT	1.6L DIESEL	GPSM(Global Positioning System Module)																																																	
TRANSIT	1.6L DIESEL	HCM(Headlamp Control Module)																																																	
TRANSIT	1.6L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
TRANSIT	1.6L DIESEL	IPM-B(Image Processing Module B)																																																	
TRANSIT	1.6L DIESEL	IPC(Instrument Panel Control Module)																																																	
TRANSIT	1.6L DIESEL	PAM(Parking Aid Module)																																																	
TRANSIT	1.6L DIESEL	PDM(Passenger's Door Module)																														V	V																		
TRANSIT	1.6L DIESEL	PSCM(Power Steering Control Module)																																																	
TRANSIT	1.6L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	1.6L DIESEL	SASM(Steering Angle Sensor Module)																																																	
TRANSIT	1.6L DIESEL	TRM(Trailer Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																				V																										V	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																																	V	V													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)																				V																										V	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)																																																
TRANSIT	2.0L	SYSTEM SEARCH																																																		
TRANSIT	2.0L	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.0L	PATS(Passive Anti Theft System)																																			V	V														
TRANSIT	2.0L	ASM(Auto Shift Manual)																																																		
TRANSIT	2.0L	ABS(Anti-Lock Brake System)																																																		
TRANSIT	2.0L	HEC(Hybrid Electrical Cluster)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SYSTEM SEARCH																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PCM(PowerTrain Control Module)			V																																														
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)																										V																							
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ACM(Audio Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	APIM(Accessory Protocol Interface Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	AHCM(Auxiliary Heater Control Module)																																			V													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	CCMii(Cruise Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FCDIM(Front Control/Display Interface Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	GPSM(Global Positioning System Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	HCM(Headlamp Control Module)																																								V								
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-A(Image Processing Module A)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-B(Image Processing Module B)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FFH(Fuel Fired Coolant Heating Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PRB(Power Running Board)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SRM(Speech Recognition Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SASM(Steering Angle Sensor Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TBC(Trailer Brake Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TRM(Trailer Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SYSTEM SEARCH																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PCM(PowerTrain Control Module)			V																																														
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)																										V																								
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ACM(Audio Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiture the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	APIM(Accessory Protocol Interface Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	AHCM(Auxiliary Heater Control Module)																																			V												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	CCMii(Cruise Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FCDIM(Front Control/Display Interface Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	GPSM(Global Positioning System Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	HCM(Headlamp Control Module)																																							V								
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-A(Image Processing Module A)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-B(Image Processing Module B)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FFH(Fuel Fired Coolant Heating Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PRB(Power Running Board)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SRM(Speech Recognition Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SASM(Steering Angle Sensor Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TBC(Trailer Brake Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TRM(Trailer Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	SYSTEM SEARCH																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)																			V	V																												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PATS(Passive Anti Theft System)																																	V	V														
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ASM(Auto Shift Manual)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)																										V																						
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	HEC(Hybrid Electrical Cluster)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	IPC(Instrument Panel Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	BCMii(Body Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	CSM(Central Security Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ACM(Audio Control Module)																																															
TRANSIT	2.3L DIESEL	SYSTEM SEARCH																																																	
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)																					V	V																												
TRANSIT	2.3L DIESEL	PATS(Passive Anti Theft System)																																			V	V														
TRANSIT	2.3L DIESEL	ASM(Auto Shift Manual)																																																	
TRANSIT	2.3L DIESEL	ABS(Anti-Lock Brake System)																												V																						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
TRANSIT	2.3L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	2.3L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
TRANSIT	2.3L DIESEL	IPC(Instrument Panel Control Module)																																																	
TRANSIT	2.3L DIESEL	BCMii(Body Control Module)																																																	
TRANSIT	2.3L DIESEL	ACM(Audio Control Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																												V																					
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	BCMii(Body Control Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)																																																
TRANSIT	2.4L DIESEL	SYSTEM SEARCH																																																	
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)																					V	V																													
TRANSIT	2.4L DIESEL	PATS(Passive Anti Theft System)																																				V	V													
TRANSIT	2.4L DIESEL	ASM(Auto Shift Manual)																																																	
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)																													V																					
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	2.4L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
TRANSIT	2.4L DIESEL	IPC(Instrument Panel Control Module)																																																	
TRANSIT	2.4L DIESEL	BCMii(Body Control Module)																																																	
TRANSIT	2.4L DIESEL	CSM(Central Security Module)																																																	
TRANSIT	2.4L DIESEL	ACM(Audio Control Module)																																																	
TRANSIT	2.5L DIESEL	SYSTEM SEARCH																																																	
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.5L DIESEL	PATS(Passive Anti Theft System)																																				V	V													
TRANSIT	2.5L DIESEL	ASM(Auto Shift Manual)																																																	
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																																																
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																																																
TRANSIT	2.5L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
TRANSIT	2.5L DIESEL	CSM(Central Security Module)																																																	
TRANSIT	2.5L DIESEL	Passive Antitheft																																																	
TRANSIT	2.5L DIESEL	RIM(Remote Immobilizer Module)																																																	
TRANSIT	2.5L DIESEL	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Conffiture All Three sensros Togethers.	ESP Conffiture the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
TRANSIT	3.2L DIESEL	SYSTEM SEARCH																																																	
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)																					V	V																											
TRANSIT	3.2L DIESEL	ABS(Anti-Lock Brake System)																												V																					
TRANSIT	3.2L DIESEL	ACM(Audio Control Module)																																																	
TRANSIT	3.2L DIESEL	BCMii(Body Control Module)																																																	
TRANSIT	3.2L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
TRANSIT	3.2L DIESEL	IPC(Instrument Panel Control Module)																																																	
TRANSIT	3.2L DIESEL	PAM(Parking Aid Module)																																																	
TRANSIT	3.2L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	3.2L DIESEL	SRM(Speech Recognition Module)																																																	
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																				V																										V	
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																																		V	V													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)																				V																										V	
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)																																															
RANGER	2.2 Diesel	SYSTEM SEARCH																																																	
RANGER	2.2 Diesel	PCM(PowerTrain Control Module)					V																																												
RANGER	2.2 Diesel	ABS(Anti-Lock Brake System)																																																	
RANGER	2.2 Diesel	ACM(Audio Control Module)																																																	
RANGER	2.2 Diesel	BCMii(Body Control Module)																																																	
RANGER	2.2 Diesel	DDM(Driver's Door Module)																																																	
RANGER	2.2 Diesel	FCDIM(Front Control/Display Interface Module)																																																	
RANGER	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Configure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
RANGER	2.2 Diesel	IPC(Instrument Panel Control Module)																																																		
RANGER	2.2 Diesel	PAM(Parking Aid Module)																																																		
RANGER	2.2 Diesel	PDM(Passenger's Door Module)																																																		
RANGER	2.2 Diesel	RCM(Restraint Control Module)																																																		
RANGER	2.2 Diesel	SRM(Speech Recognition Module)																																																		
RANGER	2.2 Diesel	TBM(Tracking And Blocking Module)																																																		
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																		
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																		
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																		
RANGER	2.2 Diesel	TRM(Trailer Module)																																																		
RANGER	2.2 Diesel	PATS(Passive anti theft system)-BETA																																														V	V			
RANGER	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																																		
RANGER	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																																																		
RANGER	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																																																		
RANGER	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																																																		
RANGER	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																																																		
RANGER	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)-BETA																																														V	V			
RANGER	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																																		
RANGER	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																																																		
RANGER	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																																																		
RANGER	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																																																		
RANGER	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																																																		
RANGER	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)-BETA																																														V	V			
RANGER	3.2 Diesel	~ 2015	SYSTEM SEARCH																																																	
RANGER	3.2 Diesel	~ 2015	PCM(PowerTrain Control Module)				V																																													
RANGER	3.2 Diesel	~ 2015	ABS(Anti-Lock Brake System)																																																	
RANGER	3.2 Diesel	~ 2015	ACM(Audio Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	BCMii(Body Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	DDM(Driver's Door Module)																																																	
RANGER	3.2 Diesel	~ 2015	FCDIM(Front Control/Display Interface Module)																																																	
RANGER	3.2 Diesel	~ 2015	HVAC(Heating Ventilation Air Conditioning)																																																	
RANGER	3.2 Diesel	~ 2015	IPC(Instrument Panel Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	PAM(Parking Aid Module)																																																	
RANGER	3.2 Diesel	~ 2015	PDM(Passenger's Door Module)																																																	
RANGER	3.2 Diesel	~ 2015	RCM(Restraint Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	SRM(Speech Recognition Module)																																																	
RANGER	3.2 Diesel	~ 2015	TBM(Tracking And Blocking Module)																																																	
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	TRM(Trailer Module)																																																	
RANGER	3.2 Diesel	~ 2015	PATS(Passive anti theft system)-BETA																																													V	V			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
RANGER	3.2 Diesel	2015 ~	SYSTEM SEARCH																																																	
RANGER	3.2 Diesel	2015 ~	PCM(PowerTrain Control Module)		V		V				V																																										
RANGER	3.2 Diesel	2015 ~	TCM(Transmission Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	ABS(Anti-Lock Brake System)																																																		
RANGER	3.2 Diesel	2015 ~	ACM(Audio Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	APIM(Accessory Protocol Interface Module)																																																		
RANGER	3.2 Diesel	2015 ~	ATCM(All Terrain Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	BCM(Body Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	C-CM(Cruise Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	DDM(Driver's Door Module)																																																		
RANGER	3.2 Diesel	2015 ~	FCDIM(Front Control/Display Interface Module)																																																		
RANGER	3.2 Diesel	2015 ~	FCIM(Front Controls Interface Module)																																																		
RANGER	3.2 Diesel	2015 ~	GPSM(Global Positioning System Module)																																																		
RANGER	3.2 Diesel	2015 ~	GWM(Gateway Module A)																																																		
RANGER	3.2 Diesel	2015 ~	HCM(Headlamp Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	HUD(Head Up Display)																																																		
RANGER	3.2 Diesel	2015 ~	IPC(Instrument Panel Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	IPM-A(Image Processing Module A)																																																		
RANGER	3.2 Diesel	2015 ~	PAM(Parking Aid Module)																																																		
RANGER	3.2 Diesel	2015 ~	PDM(Passenger's Door Module)																																																		
RANGER	3.2 Diesel	2015 ~	PSCM(Power Steering Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	RCM(Restraint Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	RGTM(Rear Gate/Trunk Module)																																																		
RANGER	3.2 Diesel	2015 ~	RTM(Radio Transceiver Module)																																																		
RANGER	3.2 Diesel	2015 ~	SCCM(Streering Colume Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	TCU(Telemetic Control Unit Module)																																																		
RANGER	3.2 Diesel	2015 ~	TRM(Trailer Module)																																																		
RANGER	2.5 Gasoline	SYSTEM SEARCH																																																			
RANGER	2.5 Gasoline	PCM(PowerTrain Control Module)																																																			
RANGER	2.5 Gasoline	ABS(Anti-Lock Brake System)																																																			
RANGER	2.5 Gasoline	ACM(Audio Control Module)																																																			
RANGER	2.5 Gasoline	BCMii(Body Control Module)																																																			
RANGER	2.5 Gasoline	DDM(Driver's Door Module)																																																			
RANGER	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																																																			
RANGER	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																																																			
RANGER	2.5 Gasoline	IPC(Instrument Panel Control Module)																																																			
RANGER	2.5 Gasoline	PAM(Parking Aid Module)																																																			
RANGER	2.5 Gasoline	PDM(Passenger's Door Module)																																																			
RANGER	2.5 Gasoline	RCM(Restraint Control Module)																																																			
RANGER	2.5 Gasoline	SRM(Speech Recognition Module)																																																			
RANGER	2.5 Gasoline	TBM(Tracking And Blocking Module)																																																			
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																		
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																		
RANGER	2.5 Gasoline	TRM(Trailer Module)																																																		
RANGER	2.5 Gasoline	PATS(Passive anti theft system)-BETA																																													V	V			
BETA-TEST	FOCUS-1.6L Zetec Rocam	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	MC(Message Center)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CMR(Camera Module Rear)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	D_DCU(Driver Door Control Unit)																					V																														
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EPS(Electronic Power Steering)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)																					V																														
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GDM(Generic Display Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	NAV(Navigation System)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RL_DCU(Rear Left Door Control Unit)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RR_DCU(Rear Right Door Control Unit)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	TCM(Transmission Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PCM(PowerTrain Control Module)																																															V	V	V
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ABS(Anti-Lock Brake System)															V																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CMR(Camera Module Rear)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	D_DCU(Driver Door Control Unit)																					V																													
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EPS(Electronic Power Steering)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FACM(Fuel Additive Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																					V																													
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EPS(Electronic Power Steering)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GDM(Generic Display Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	NAV(Navigation System)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SRM(Speech Recognition Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	TCM(Transmission Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																					V																													
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EPS(Electronic Power Steering)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Conifiure All Three sensros Togethers.	ESP Conifiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GDM(Generic Display Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	NAV(Navigation System)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PDM(Passenger's Door Module)																					V																														
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RL_DCU(Rear Left Door Control Unit)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RR_DCU(Rear Right Door Control Unit)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SRM(Speech Recognition Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PCM(Powertrain Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	D_DCU(Driver Door Control Unit)																					V																														
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EPS(Electronic power steering)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	GEM(Generic Electronic Module)																					V																														
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TBM(Tracking and Blocking Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TCM(Transmission Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PATS(Passive Anti Theft System)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PCM(PowerTrain Control Module)																						V																												V	
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CMR(Camera Module Rear)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	D_DCU(Driver Door Control Unit)																					V																														
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EPS(Electronic Power Steering)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FACM(Fuel Additive Control Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	GEM(Generic Electronic Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Conifiure All Three sensros Togethers.	ESP Conifiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	HCM(Headlamp Control Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	IC(Instrument Cluster)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PDM(Passenger's Door Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PAM(Parking Aid Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RCM(Restraint Control Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RETM(Rear Entertainment Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RKE(Remote Keyless Entry)																																																			
BETA-TEST	FUSION GASOLINE1.4L	SYSTEM SEARCH																																																			
BETA-TEST	FUSION GASOLINE1.4L	PCM(Powertrain Control Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FUSION GASOLINE1.4L	ACM(Audio Control Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	APIM(Accessory Protocol Interface Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	BCMii(Body Control Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	DDM(Driver's Door Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	FDSM(Front Distance Sensing Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	FCDIM(Front Control/Display Interface Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	GPSM(Global Positioning System Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	GWM(Gateway Module A)																																																			
BETA-TEST	FUSION GASOLINE1.4L	HVAC(Heating Ventilation Air Conditioning)																																																			
BETA-TEST	FUSION GASOLINE1.4L	IPC(Instrument Panel Control Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	PDM(Passenger's Door Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	PSCM(Power Steering Control Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	RCM(Restraint Control Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	RFA(Remote Function Actuator)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SYSTEM SEARCH																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	TCM(Transmission Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IC(Instrument Cluster)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	GEM(Generic Electronic Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ACM(Audio Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	BCMii(Body Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	FCDIM(Front Control/Display Interface Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IPC(Instrument Panel Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PSCM(Power Steering Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RCM(Retraint Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RFA(Remote Function Actuator)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SRM(Speech Recognition Module)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SYSTEM SEARCH																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Configure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	TCM(Transmission Control Module)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	IC(Instrument Cluster)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ACM(Audio Control Module)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)																																																			
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																																			
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																																																			
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	SYSTEM SEARCH																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	TCM(Transmission Control Module)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	IC(Instrument Cluster)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	ACM(Audio Control Module)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	GEM(Generic Electronic Module)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	SRM(Speech Recognition Module)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	PATS(Passive Anti Theft System)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SYSTEM SEARCH																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ACM(Audio Control Module)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	GEM(Generic Electronic Module)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	IC(Instrument Cluster)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SRM(Speech Recognition Module)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PATS(Passive Anti Theft System)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	SYSTEM SEARCH																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PCM(PowerTrain Control Module)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	IC(Instrument Cluster)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RCM(Restraint Control Module)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RKE(Remote Keyless Entry)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	TCM(Transmission Control Module)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PATS(Passive Anti Theft System)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	SYSTEM SEARCH																																																			
BETA-TEST	MONDEO-2.0L DIESEL	PCM(PowerTrain Control Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
BETA-TEST	MONDEO-2.0L DIESEL	ABS(Anti-Lock Brake System)															V														V																						
BETA-TEST	MONDEO-2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																					V														
BETA-TEST	MONDEO-2.0L DIESEL	BCMii(Body Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	CCMii(Cruise Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	CMR(Camera Module Rear)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	DDM(Driver's Door Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	DSM(Driver's Seat Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	HCM(Headlamp Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	IPC(Instrument Panel Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	PAM(Parking Aid Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	PBM(Parking Brake Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	PDM(Passenger's Door Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	PSCM(Power Steering Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	RCM(Restraint Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	RFA(Remote Function Actuator)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	SRM(Speech Recognition Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	TCM(Transmission Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	TRM(Trailer Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	SYSTEM SEARCH																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	PCM(PowerTrain Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	BCMii(Body Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	CCMii(Cruise Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	CMR(Camera Module Rear)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	DDM(Driver's Door Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	DSM(Driver's Seat Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	HCM(Headlamp Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	PAM(Parking Aid Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	PBM(Parking Brake Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	PDM(Passenger's Door Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	PSCM(Power Steering Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	RCM(Restraint Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	RFA(Remote Function Actuator)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	SRM(Speech Recognition Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	TCM(Transmission Control Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the DPF Learned Values	Reset the DPF Differential Pressure Sensor Learned Values	Reset the Mass Air Flow Sensor Learned Values	Deactivation the Passenger Airbag Switch	Activate the Passenger airbag Switch	Reset The Exhaust Gas Recirculation Valve Learned Values	Reset the Water in Fuel Warning Indicator	Ignition Key Erase	Ignition Key Programming	PCM/IC Paramenter Reset	Odometer Write	RCM Parameter reset / configuration	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Reset the DPF differential pressure sensor learned value	Reset the water in fuel warning indicator	Reset the Turbo Charger Learned Values	Reset the Low Pressure Fuel Pump Learned Values	Reset the Active Grille Shutter Learned Values	Reset the Low Pressure Fule System Learned Values	Reset the Nitrogen Oxide(NOX) Sensor Learned Values	Configure the steering angle sensor	ABS Module Initialization	Passenger Window Motor Test	Power Window Initialization Passenger Side	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Ignition keys erase	Ignition keys program	Prime the Fuel System	Rear Tones Test	Tones Test	Wiper Moter Module Calibration	CCMii Sensor Alignment	Driver Window Motor Test	Power Window Initialization Driver Side	HeadLamp Alignment	RCM Configuration	Ignition key code erase and program	Program additional ignition key	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset
BETA-TEST	MONDEO-2.5L GASOLINE	TRM(Trailer Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	SYSTEM SEARCH																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	PCM(PowerTrain Control Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	ACM(Audio Control Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	CDP(Compact Disc Player)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	GDM(Generic Display Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	GEM(Generic Electronic Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	NAV(Navigation System)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	RCM(Restraint Control Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	RETM(Rear Entertainment Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	SRM(Speech Recognition Module)																																																	
BETA-TEST	F-150 5.4L	SYSTEM SEARCH																																																	
BETA-TEST	F-150 5.4L	PCM(PowerTrain Control Module)																																																	
BETA-TEST	F-150 5.4L	4X4(4x4 Control Module)																																																	
BETA-TEST	F-150 5.4L	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	F-150 5.4L	DSM(Driver Seat Module)																																																	
BETA-TEST	F-150 5.4L	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	F-150 5.4L	IC(Instrument Cluster)																																																	
BETA-TEST	F-150 5.4L	PAM(Parking Aid Module)																																																	
BETA-TEST	F-150 5.4L	RCM(Restraint Control Module)																																																	
BETA-TEST	F-150 5.4L	VSM(Vehicle Security Module)																																																	
BETA-TEST	F-150 5.4L	PATS(Passive Anti Theft System)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	SYSTEM SEARCH																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PCM(PowerTrain Control Module)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	IC(Instrument Cluster)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PAM(Parking Aid Module)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	RCM(Restraint Control Module)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	VSM(Vehicle Security Module)																																																	
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																	
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																	
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
Incode Calculator	~2010.05	All model																																																	
ESCAPE	Up to 2004	SYSTEM SEARCH																																																	
ESCAPE	Up to 2004	PCM(PowerTrain Control Module)																																																	
ESCAPE	Up to 2004	Immobilizer																																																	
ESCAPE	Up to 2004	ABS(Anti-Lock Brake System)																																																	
ESCAPE	Up to 2004	RCM(Restraint Control Module)																																																	
ESCAPE	Up to 2004	GEM(Generic Electronic Module)																																																	
ESCAPE	From 2004	SYSTEM SEARCH																																																	
ESCAPE	From 2004	PCM(PowerTrain Control Module)																																																	
ESCAPE	From 2004	PATS(Passive anti theft system)																																																	
ESCAPE	From 2004	ABS(Anti-Lock Brake System)																																																	
ESCAPE	From 2004	ABS(Anti-Lock Brake System)																																																	
ESCAPE	From 2004	RCM(Restraint Control Module)																																																	
ESCAPE	From 2004	IC(Instrument Cluster)																																																	
ESCAPE	From 2004	GEM(Generic Electronic Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	SYSTEM SEARCH																																																
EXPLORER	2011 MY	3.5L TiCVT	PCM(Powertrain Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	ABS(Anti-Lock Brake System)																																																
EXPLORER	2011 MY	3.5L TiCVT	ACM(Audio Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	APIM(Accessory Protocol Interface Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	BCM(Body Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	ATCM(All Terrain Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	C-CM(Cruise Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	CLM(Column Lock Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	DCSM(Driver-Dual Climate Contol Seat Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	DSM(Driver Seat Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	DSP(Digital Signal Processing Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	FCIM(Front Controls Interface Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	FCDIM(Front Control/Display Interface Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	FLM(Front Lighting Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	GPSM(Global Positioning System Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	HUD(Head Up Display)																																																
EXPLORER	2011 MY	3.5L TiCVT	HVAC(Heating Ventilation Air Conditioning)																																																
EXPLORER	2011 MY	3.5L TiCVT	IPC(Instrument Panel Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	LTM(Liftgate/Trunk Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	OCSM(Occupant Classification System Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	PAM(Parking Aid Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	PSCM(Power Steering Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	RCM(Restraint Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	RFA(Remote Function Actuator)																																																
EXPLORER	2011 MY	3.5L TiCVT	RLCM-A(Rear Lighting Control Module A)																																																
EXPLORER	2011 MY	3.5L TiCVT	SCCM(Streering Colume Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
EXPLORER	2011 MY	3.5L TiCVT	SOD-L(Side Obstacle Detection Control Module Left)																																																
EXPLORER	2011 MY	3.5L TiCVT	SOD-R(Side Obstacle Detection Control Module Right)																																																
EXPLORER	2011 MY	3.5L TiCVT	TPM(Tire Pressure Monitor)																																																
EXPLORER	2010 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER	2010 MY	4.6L	PCM(Powertrain Control Module)																																																
EXPLORER	2010 MY	4.6L	TCM(Transmission Control Module)																																																
EXPLORER	2010 MY	4.6L	4X4(4x4 Control Module)																																																
EXPLORER	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																
EXPLORER	2010 MY	4.6L	ACM(Audio Control Module)																																																
EXPLORER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																
EXPLORER	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																
EXPLORER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																
EXPLORER	2010 MY	4.6L	DSM(Driver's Seat Module)																																																
EXPLORER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
EXPLORER	2010 MY	4.6L	IC(Instrument Cluster)																																																
EXPLORER	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																
EXPLORER	2010 MY	4.6L	PAM(Parking Aid Module)																																																
EXPLORER	2010 MY	4.6L	PRB(Power Running Board)																																																
EXPLORER	2010 MY	4.6L	RCM(Restraint Control Module)																																																
EXPLORER	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																
EXPLORER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
EXPLORER	2009 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER	2009 MY	4.6L	PCM(Powertrain Control Module)																																																
EXPLORER	2009 MY	4.6L	TCM(Transmission Control Module)																																																
EXPLORER	2009 MY	4.6L	4X4(4x4 Control Module)																																																
EXPLORER	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																
EXPLORER	2009 MY	4.6L	ACM(Audio Control Module)																																																
EXPLORER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																
EXPLORER	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																
EXPLORER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																
EXPLORER	2009 MY	4.6L	DSM(Driver's Seat Module)																																																
EXPLORER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
EXPLORER	2009 MY	4.6L	IC(Instrument Cluster)																																																
EXPLORER	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																
EXPLORER	2009 MY	4.6L	PAM(Parking Aid Module)																																																
EXPLORER	2009 MY	4.6L	PRB(Power Running Board)																																																
EXPLORER	2009 MY	4.6L	RCM(Restraint Control Module)																																																
EXPLORER	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																
EXPLORER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
EXPLORER	2008 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER	2008 MY	4.6L	PCM(Powertrain Control Module)																																																
EXPLORER	2008 MY	4.6L	TCM(Transmission Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
EXPLORER	2008 MY	4.6L	4X4(4x4 Control Module)																																																
EXPLORER	2008 MY	4.6L	ABS(Anti-Lock Brake System)																																																
EXPLORER	2008 MY	4.6L	ACM(Audio Control Module)																																																
EXPLORER	2008 MY	4.6L	DSM(Driver's Seat Module)																																																
EXPLORER	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																
EXPLORER	2008 MY	4.6L	GEM(Generic Electronic Module)																																																
EXPLORER	2008 MY	4.6L	IC(Instrument Cluster)																																																
EXPLORER	2008 MY	4.6L	OCSM(Occupant Classification System Module)																																																
EXPLORER	2008 MY	4.6L	PAM(Parking Aid Module)																																																
EXPLORER	2008 MY	4.6L	PRB(Power Running Board)																																																
EXPLORER	2008 MY	4.6L	RCM(Restraint Control Module)																																																
EXPLORER	2008 MY	4.6L	RETM(Rear Entertainment Module)																																																
EXPLORER	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
EXPLORER	2007 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER	2007 MY	4.6L	PCM(Powertrain Control Module)																																																
EXPLORER	2007 MY	4.6L	TCM(Transmission Control Module)																																																
EXPLORER	2007 MY	4.6L	4X4(4x4 Control Module)																																																
EXPLORER	2007 MY	4.6L	ABS(Anti-Lock Brake System)																																																
EXPLORER	2007 MY	4.6L	ACM(Audio Control Module)																																																
EXPLORER	2007 MY	4.6L	DSM(Driver's Seat Module)																																																
EXPLORER	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																
EXPLORER	2007 MY	4.6L	GEM(Generic Electronic Module)																																																
EXPLORER	2007 MY	4.6L	IC(Instrument Cluster)																																																
EXPLORER	2007 MY	4.6L	OCSM(Occupant Classification System Module)																																																
EXPLORER	2007 MY	4.6L	PAM(Parking Aid Module)																																																
EXPLORER	2007 MY	4.6L	PRB(Power Running Board)																																																
EXPLORER	2007 MY	4.6L	RCM(Restraint Control Module)																																																
EXPLORER	2007 MY	4.6L	RETM(Rear Entertainment Module)																																																
EXPLORER	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
EXPLORER	2006 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER	2006 MY	4.6L	PCM(Powertrain Control Module)																																																
EXPLORER	2006 MY	4.6L	TCM(Transmission Control Module)																																																
EXPLORER	2006 MY	4.6L	4X4(4x4 Control Module)																																																
EXPLORER	2006 MY	4.6L	ABS(Anti-Lock Brake System)																																																
EXPLORER	2006 MY	4.6L	ACM(Audio Control Module)																																																
EXPLORER	2006 MY	4.6L	DSM(Driver's Seat Module)																																																
EXPLORER	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																
EXPLORER	2006 MY	4.6L	GEM(Generic Electronic Module)																																																
EXPLORER	2006 MY	4.6L	IC(Instrument Cluster)																																																
EXPLORER	2006 MY	4.6L	OCSM(Occupant Classification System Module)																																																
EXPLORER	2006 MY	4.6L	PAM(Parking Aid Module)																																																
EXPLORER	2006 MY	4.6L	PRB(Power Running Board)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
EXPLORER	2006 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2006 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2000 MY	SYSTEM SEARCH																																																		
EXPLORER	2000 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	2000 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	2000 MY	RCM(Restraint Control Module)																																																		
EXPLORER	2000 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER	2000 MY	GEM(Generic Electronic Module)																																																		
EXPLORER	2000 MY	PAM(Parking Aid Module)																																																		
EXPLORER	1999 MY	SYSTEM SEARCH																																																		
EXPLORER	1999 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	1999 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	1999 MY	RCM(Restraint Control Module)																																																		
EXPLORER	1999 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER	1999 MY	PAM(Parking Aid Module)																																																		
EXPLORER	1998 MY	SYSTEM SEARCH																																																		
EXPLORER	1998 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	1998 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	1998 MY	RCM(Restraint Control Module)																																																		
EXPLORER	1998 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER	1997 MY	SYSTEM SEARCH																																																		
EXPLORER	1997 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	1997 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	1997 MY	RCM(Restraint Control Module)																																																		
EXPLORER	1997 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	RCM(Restraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
EXPLORER SPORT-TRAC	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																
EXPLORER SPORT-TRAC	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	PCM(Powertrain Control Module)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	TCM(Transmission Control Module)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	4X4(4x4 Control Module)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	ACM(Audio Control Module)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	DSM(Driver's Seat Module)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	IC(Instrument Cluster)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	PAM(Parking Aid Module)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	PRB(Power Running Board)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	RCM(Restraint Control Module)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																
EXPLORER SPORT-TRAC	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	PCM(Powertrain Control Module)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	TCM(Transmission Control Module)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	4X4(4x4 Control Module)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	ABS(Anti-Lock Brake System)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	ACM(Audio Control Module)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	DSM(Driver's Seat Module)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	GEM(Generic Electronic Module)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	IC(Instrument Cluster)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	OCSM(Occupant Classification System Module)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	PAM(Parking Aid Module)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	PRB(Power Running Board)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	RCM(Restraint Control Module)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	RETM(Rear Entertainment Module)																																																
EXPLORER SPORT-TRAC	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	PCM(Powertrain Control Module)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	TCM(Transmission Control Module)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	4X4(4x4 Control Module)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	ABS(Anti-Lock Brake System)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	ACM(Audio Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
EXPLORER SPORT-TRAC	2007 MY	4.6L	DSM(Driver's Seat Module)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	GEM(Generic Electronic Module)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	IC(Instrument Cluster)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	OCSM(Occupant Classification System Module)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	PAM(Parking Aid Module)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	PRB(Power Running Board)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	RCM(Restraint Control Module)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	RETM(Rear Entertainment Module)																																																
EXPLORER SPORT-TRAC	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	SYSTEM SEARCH																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	PCM(Powertrain Control Module)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	TCM(Transmission Control Module)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	4X4(4x4 Control Module)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	ABS(Anti-Lock Brake System)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	ACM(Audio Control Module)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	DSM(Driver's Seat Module)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	GEM(Generic Electronic Module)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	IC(Instrument Cluster)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	OCSM(Occupant Classification System Module)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	PAM(Parking Aid Module)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	PRB(Power Running Board)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	RCM(Restraint Control Module)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	RETM(Rear Entertainment Module)																																																
EXPLORER SPORT-TRAC	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	BCM(Body Control Module)																																																
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	GPSM(Global Positioning System Module)																																																
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
ECOSPORT	1.5L	DURATEC VCT	SYSTEM SEARCH																																																
ECOSPORT	1.5L	DURATEC VCT	PCM(Powertrain Control Module)																																																
ECOSPORT	1.5L	DURATEC VCT	ABS(Anti-Lock Brake System)																																																
ECOSPORT	1.5L	DURATEC VCT	ACM(Audio Control Module)																																																
ECOSPORT	1.5L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																																																
ECOSPORT	1.5L	DURATEC VCT	BCMii(Body Control Module)																																																
ECOSPORT	1.5L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																																																
ECOSPORT	1.5L	DURATEC VCT	GPSM(Global Positioning System Module)																																																
ECOSPORT	1.5L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																
ECOSPORT	1.5L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																
ECOSPORT	1.5L	DURATEC VCT	PSCM(Power Steering Control Module)																																																
ECOSPORT	1.5L	DURATEC VCT	RCM(Restraint Control Module)																																																
ECOSPORT	1.5L	DURATEC VCT	RFA(Remote Function Actuator)																																																
ECOSPORT	1.5L	DURATEC VCT	TCM(Transmission Control Module)																																																
FIESTA	1.25L	DURATEC 16V	SYSTEM SEARCH																																																
FIESTA	1.25L	DURATEC 16V	PCM(PowerTrain Control Module)																																																
FIESTA	1.25L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																
FIESTA	1.25L	DURATEC 16V	ACM(Audio Control Module)																																																
FIESTA	1.25L	DURATEC 16V	APIM(Accessory Protocol Interface Module)																																																
FIESTA	1.25L	DURATEC 16V	BCMii(Body Control Module)																																																
FIESTA	1.25L	DURATEC 16V	DDM(Driver's Door Module)																																																
FIESTA	1.25L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																																																
FIESTA	1.25L	DURATEC 16V	FDSM(Front Distance Sensing Module)																																																
FIESTA	1.25L	DURATEC 16V	GPSM(Global Positioning System Module)																																																
FIESTA	1.25L	DURATEC 16V	HVAC(Heating Ventilation Air Conditioning)																																																
FIESTA	1.25L	DURATEC 16V	IPC(Instrument Panel Control Module)																																																
FIESTA	1.25L	DURATEC 16V	PDM(Passenger's Door Module)																																																
FIESTA	1.25L	DURATEC 16V	PSCM(Power Steering Control Module)																																																
FIESTA	1.25L	DURATEC 16V	RCM(Restraint Control Module)																																																
FIESTA	1.25L	DURATEC 16V	RFA(Remote Function Actuator)																																																
FIESTA	1.4L GASOLINE	SYSTEM SEARCH																																																	
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)																																																	
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)																																																	
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.4L GASOLINE	APIM(Accessory Protocol Interface Module)																																																	
FIESTA	1.4L GASOLINE	PSCM(Power Steering Control Module)																																																	
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)																																																	
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)																																																	
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.4L GASOLINE	GEM(Generic Electronic Module)																																																	
FIESTA	1.4L GASOLINE	BCMii(Body Control Module)																																																	
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.4L GASOLINE	RFA(Remote Function Actuator)																																																	
FIESTA	1.4L GASOLINE	SRM(Speech Recognition Module)																																																	
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)																																																	
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)																																																	
FIESTA	1.4L GASOLINE	DDM(Driver's Door Module)																																																	
FIESTA	1.4L GASOLINE	FDSM(Front Distance Sensing Module)																																																	
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.4L GASOLINE	GPSM(Global Positioning System Module)																																																	
FIESTA	1.4L GASOLINE	PDM(Passenger's Door Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																	
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.5L	TiVCT	SYSTEM SEARCH																																																	
FIESTA	1.5L	TiVCT	PCM(PowerTrain Control Module)																																																	
FIESTA	1.5L	TiVCT	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.5L	TiVCT	ACM(Audio Control Module)																																																	
FIESTA	1.5L	TiVCT	BCMii(Body Control Module)																																																	
FIESTA	1.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.5L	TiVCT	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.5L	TiVCT	PSCM(Power Steering Control Module)																																																	
FIESTA	1.5L	TiVCT	RCM(Retraint Control Module)																																																	
FIESTA	1.5L	TiVCT	RFA(Remote Function Actuator)																																																	
FIESTA	1.5L	TiVCT	SRM(Speech Recognition Module)																																																	
FIESTA	1.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.5L	TiVCT	TCM(Transmission Control Module)																																																	
FIESTA	1.6L GASOLINE	SYSTEM SEARCH																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)																																																	
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)																																																	
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.6L GASOLINE	PSCM(Power Steering Control Module)																																																	
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)																																																	
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)																																																	
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)																																																	
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)																																																	
FIESTA	1.6L GASOLINE	BCMii(Body Control Module)																																																	
FIESTA	1.6L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)																																																	
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)																																																	
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)																																																	
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)																																																	
FIESTA	1.6L ZETEC ROCAM	SYSTEM SEARCH																																																	
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)																																																	
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)																																																	
FIESTA	1.6L ZETEC ROCAM	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.6L ZETEC ROCAM	IC(Instrument Cluster)																																																	
FIESTA	1.6L ZETEC ROCAM	RCM(Restraint Control Module)																																																	
FIESTA	1.6L ZETEC ROCAM	RKE(Remote Keyless Entry)																																																	
FIESTA	1.6L ZETEC ROCAM	TCM(Transmission Control Module)																																																	
FIESTA	1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																																	
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																	
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																	
FIESTA	1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																																																	
FIESTA	1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																																																	
FIESTA	2.0L GASOLINE	SYSTEM SEARCH																																																	
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																	
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																	
FIESTA	2.0L GASOLINE	ACM(Audio Control Module)																																																	
FIESTA	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
FIESTA	2.0L GASOLINE	GEM(Generic Electronic Module)																																																	
FIESTA	2.0L GASOLINE	IC(Instrument Cluster)																																																	
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)																																																	
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)																																																	
FIESTA	2.0L GASOLINE	RCM(Restraint Control Module)																																																	
FIESTA	2.0L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
FIGO	1.4L DIESEL	SYSTEM SEARCH																																																	
FIGO	1.4L DIESEL	PCM(Powertrain Control Module)																																																	
FIGO	1.4L DIESEL	ABS(Anti-Lock Brake System)																																																	
FIGO	1.4L DIESEL	IC(Instrument Cluster)																																																	
FIGO	1.4L DIESEL	RCM(Restraint Control Module)																																																	
FIGO	1.6L	DURATEC 16V	SYSTEM SEARCH																																																
FIGO	1.6L	DURATEC 16V	PCM(Powertrain Control Module)																																																
FIGO	1.6L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																
FIGO	1.6L	DURATEC 16V	GEM(Generic Electronic Module)																																																
FIGO	1.6L	DURATEC 16V	IC(Instrument Cluster)																																																
FIGO	1.6L	DURATEC 16V	RCM(Restraint Control Module)																																																
FIGO	1.6L	DURATEC 16V	TCM(Transmission Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM(Front Distance Sensing Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																	
FOCUS	1.4L	DURATEC 16V	SYSTEM SEARCH																																																	
FOCUS	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.4L	DURATEC 16V	ACM(Audio Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	CDP(Compact Disc Player)																																																	
FOCUS	1.4L	DURATEC 16V	D_DCU(Driver Door Control Unit)																																																	
FOCUS	1.4L	DURATEC 16V	GDM(Generic Display Module)																																																	
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																																																	
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																																																	
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	1.4L	DURATEC 16V	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS	1.4L	DURATEC 16V	IC(Instrument Cluster)																																																	
FOCUS	1.4L	DURATEC 16V	NAV(Navigation System)																																																	
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)																																																	
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)																																																	
FOCUS	1.4L	DURATEC 16V	PDM(Passenger's Door Module)																																																	
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	RKE(Remote Keyless Entry)																																																	
FOCUS	1.4L	DURATEC 16V	CSM(Central Security Module)																																																	
FOCUS	1.4L	DURATEC 16V	HEC(Hybrid Electrical Cluster)																																																	
FOCUS	1.4L	DURATEC 16V	MC(Message Center)																																																	
FOCUS	1.4L	DURATEC 16V	RETM(Rear Entertainment Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TCM(Transmission Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body control module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	CCMii(Cruise Control Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	DDM(Driver's Door Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	DDM(Driver's Door Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FCIM(Front Controls Interface Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FDSM(Front Distance Sensing Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	GPSM(Global Positioning System Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	HCM(Headlamp Control Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	HVAC(Heating Ventilation Air Conditioning)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	IPM-A(Image Processing Module A)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	IPC(Instrument Panel Control Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PAM(Parking Aid Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PDM(Passenger's Door Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PSCM(Power Steering Control Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	RCM(Restraint Control Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	RFA(Remote Function Actuator)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SASM(Steering Angle Sensor Module)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SOD-L(Side Obstacle Detection Control Module Left)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SOD-R(Side Obstacle Detection Control Module Right)																																																
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	TRM(Trailer Module)																																																
FOCUS	1.6L GASOLINE	ZETEC SE	SYSTEM SEARCH																																																
FOCUS	1.6L GASOLINE	ZETEC SE	PCM(PowerTrain Control Module)																																																
FOCUS	1.6L GASOLINE	ZETEC SE	ABS(Anti-Lock Brake System)																																																
FOCUS	1.6L GASOLINE	ZETEC SE	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	1.6L GASOLINE	ZETEC SE	GEM(Generic Electronic Module)																																																
FOCUS	1.6L GASOLINE	ZETEC SE	RCM(Restraint Control Module)																																																
FOCUS	1.6L GASOLINE	ZETEC SE	MC(Message Center)																																																
FOCUS	1.6L GASOLINE	DURATEC	SYSTEM SEARCH																																																
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)																																																
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)																																																
FOCUS	1.6L GASOLINE	DURATEC	ACM(Audio Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	CDP(Compact Disc Player)																																																
FOCUS	1.6L GASOLINE	DURATEC	D_DCU(Driver Door Control Unit)																																																
FOCUS	1.6L GASOLINE	DURATEC	GDM(Generic Display Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	1.6L GASOLINE	DURATEC	FFH(Fuel Fired Coolant Heating Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FOCUS	1.6L GASOLINE	DURATEC	IC(Instrument Cluster)																																																
FOCUS	1.6L GASOLINE	DURATEC	NAV(Navigation System)																																																
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	PDM(Passenger's Door Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	RKE(Remote Keyless Entry)																																																
FOCUS	1.6L GASOLINE	DURATEC	RL_DCU(Rear Left Door Control Unit)																																																
FOCUS	1.6L GASOLINE	DURATEC	RR_DCU(Rear Right Door Control Unit)																																																
FOCUS	1.6L GASOLINE	DURATEC	CSM(Central Security Module)																																																
FOCUS	1.6L GASOLINE	DURATEC	HEC(Hybrid Electrical Cluster)																																																
FOCUS	1.6L GASOLINE	DURATEC	MC(Message Center)																																																
FOCUS	1.6L GASOLINE	DURATEC	PATS(Passive Anti Theft System)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SYSTEM SEARCH																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TCM(Transmission Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	APIM(Accessory Protocol Interface Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	BCMii(Body Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	CCMii(Cruise Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DDM(Driver's Door Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DSP(Digital Signal Processing Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCIM(Front Controls Interface Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FDSM(Front Distance Sensing Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HCM(Headlamp Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-A(Image Processing Module A)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-B(Image Processing Module B)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPC(Instrument Panel Control Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)																																																
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PSCM(Power Steering Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RFA(Remote Function Actuator)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SASM(Steering Angle Sensor Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SRM(Speech Recognition Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TRM(Trailer Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PATS(Passive Anti Theft System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)		V	V	V																																													
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)					V	V																																											
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)							V	V																																										
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GDM(Generic Display Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	NAV(Navigation System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Condtioning)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)					V	V			V	V	V	V	V																																				
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Condtioning)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)																																																
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CMR(Camera Module Rear)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CDP(Compact Disc Player)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPB(Electronic Parking Brake)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPS(Electronic Power Steering)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GDM(Generic Display Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HCM(Headlamp Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	IC(Instrument Cluster)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	NAV(Navigation System)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PDM(Passenger's Door Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CSM(Central Security Module)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	MC(Message Center)																																																
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SYSTEM SEARCH																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	TCM(Transmission Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ACM(Audio Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CMR(Camera Module Rear)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CDP(Compact Disc Player)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CSM(Central Security Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPB(Electronic Parking Brake)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPS(Electronic Power Steering)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GDM(Generic Display Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HCM(Headlamp Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	IC(Instrument Cluster)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	NAV(Navigation System)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PAM(Parking Aid Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PDM(Passenger's Door Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SRM(Speech Recognition Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SYSTEM SEARCH																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)														V	V																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TCM(Transmission Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	APIM(Accessory Protocol Interface Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	BCMii(Body Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	CCMii(Cruise Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DDM(Driver's Door Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DSP(Digital Signal Processing Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCIM(Front Controls Interface Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FDSM(Front Distance Sensing Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HCM(Headlamp Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-A(Image Processing Module A)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-B(Image Processing Module B)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPC(Instrument Panel Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PSCM(Power Steering Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RFA(Remote Function Actuator)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SASM(Steering Angle Sensor Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SRM(Speech Recognition Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TRM(Trailer Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PATS(Passive Anti Theft System)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	SYSTEM SEARCH																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PCM(PowerTrain Control Module)			V												V																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	TCM(Transmission Control Module)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ACM(Audio Control Module)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ABS(Anti-Lock Brake System)																V	V																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CDP(Compact Disc Player)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CMR(Camera Module Rear)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	D_DCU(Driver Door Control Unit)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	EPS(Electronic Power Steering)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FACM(Fuel Additive Control Module)					V	V																																											
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	GEM(Generic Electronic Module)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	HCM(Headlamp Control Module)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	IC(Instrument Cluster)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PDM(Passenger's Door Module)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PAM(Parking Aid Module)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RCM(Restraint Control Module)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RETM(Rear Entertainment Module)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RKE(Remote Keyless Entry)																																																	
FOCUS	2.5L GASOLINE	SYSTEM SEARCH																																																			
FOCUS	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																			
FOCUS	2.5L GASOLINE	TCM(Transmission Control Module)																																																			
FOCUS	2.5L GASOLINE	ABS(Anti-Lock Brake System)																				V	V	V																													
FOCUS	2.5L GASOLINE	EPS(Electronic Power Steering)																																																			
FOCUS	2.5L GASOLINE	RCM(Restraint Control Module)																																																			
FOCUS	2.5L GASOLINE	GEM(Generic Electronic Module)																																																			
FOCUS	2.5L GASOLINE	IC(Instrument Cluster)																																																			
FOCUS	2.5L GASOLINE	DDM(Driver's Door Module)																																																			
FOCUS	2.5L GASOLINE	PDM(Passenger's Door Module)																																																			
FOCUS	2.5L GASOLINE	MC(Message Center)																																																			
FOCUS	2.5L GASOLINE	ACM(Audio Control Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FOCUS C-MAX	1.6L DIESEL	SYSTEM SEARCH																																																		
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)			V	V	V																																													
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)						V	V																																											
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																		
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																		
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	CDP(Compact Disc Player)																																																		
FOCUS C-MAX	1.6L DIESEL	CMR(Camera Module Rear)																																																		
FOCUS C-MAX	1.6L DIESEL	D_DCU(Driver Door Control Unit)																																																		
FOCUS C-MAX	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS C-MAX	1.6L DIESEL	EPS(Electronic Power Steering)																																																		
FOCUS C-MAX	1.6L DIESEL	FACM(Fuel Additive Control Module)								V	V																																										
FOCUS C-MAX	1.6L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS C-MAX	1.6L DIESEL	GEM(Generic Electronic Module)																																																		
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	IC(Instrument Cluster)																																																		
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)																																																		
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)																																																		
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	RETM(Rear Entertainment Module)																																																		
FOCUS C-MAX	1.6L DIESEL	RKE(Remote Keyless Entry)																																																		
FOCUS C-MAX	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	BCMii(Body Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	DDM(Driver's Door Module)																																																		
FOCUS C-MAX	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)																																																		
FOCUS C-MAX	1.6L DIESEL	HVAC(Heating Ventilation Air Condtioning)																																																		
FOCUS C-MAX	1.6L DIESEL	IPM-A(Image Processing Module A)																																																		
FOCUS C-MAX	1.6L DIESEL	IPM-B(Image Processing Module B)																																																		
FOCUS C-MAX	1.6L DIESEL	IPC(Instrument Panel Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	PSCM(Power Steering Control Module)																																																		
FOCUS C-MAX	1.6L DIESEL	RFA(Remote Function Actuator)																																																		
FOCUS C-MAX	1.6L DIESEL	RGTM(Rear Gate/Trunk Module)																																																		
FOCUS C-MAX	1.6L DIESEL	SASM(Steering Angle Sensor Module)																																																		
FOCUS C-MAX	1.6L DIESEL	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	1.6L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																		
FOCUS C-MAX	1.6L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																		
FOCUS C-MAX	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FOCUS C-MAX	1.6L GASOLINE	SYSTEM SEARCH																																																		
FOCUS C-MAX	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FOCUS C-MAX	1.6L GASOLINE	ACM(Audio Control Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	CDP(Compact Disc Player)																																																		
FOCUS C-MAX	1.6L GASOLINE	CMR(Camera Module Rear)																																																		
FOCUS C-MAX	1.6L GASOLINE	D_DCU(Driver Door Control Unit)																																																		
FOCUS C-MAX	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS C-MAX	1.6L GASOLINE	EPS(Electronic Power Steering)																																																		
FOCUS C-MAX	1.6L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	GEM(Generic Electronic Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	IC(Instrument Cluster)																																																		
FOCUS C-MAX	1.6L GASOLINE	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	PDM(Passenger's Door Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	RCM(Restraint Control Module)																							V																												
FOCUS C-MAX	1.6L GASOLINE	RETM(Rear Entertainment Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	RKE(Remote Keyless Entry)																																																		
FOCUS C-MAX	1.6L GASOLINE	GDM(Generic Display Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	NAV(Navigation System)																																																		
FOCUS C-MAX	1.6L GASOLINE	RL_DCU(Rear Left Door Control Unit)																																																		
FOCUS C-MAX	1.6L GASOLINE	RR_DCU(Rear Right Door Control Unit)																																																		
FOCUS C-MAX	1.6L GASOLINE	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	TCM(Transmission Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	SYSTEM SEARCH																																																		
FOCUS C-MAX	1.8L GASOLINE	PCM(PowerTrain Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FOCUS C-MAX	1.8L GASOLINE	ACM(Audio Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	CMR(Camera Module Rear)																																																		
FOCUS C-MAX	1.8L GASOLINE	CDP(Compact Disc Player)																																																		
FOCUS C-MAX	1.8L GASOLINE	D_DCU(Driver Door Control Unit)																																																		
FOCUS C-MAX	1.8L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS C-MAX	1.8L GASOLINE	EPB(Electronic Parking Brake)																																																		
FOCUS C-MAX	1.8L GASOLINE	EPS(Electronic Power Steering)																																																		
FOCUS C-MAX	1.8L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	GDM(Generic Display Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	GEM(Generic Electronic Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	IC(Instrument Cluster)																																																		
FOCUS C-MAX	1.8L GASOLINE	NAV(Navigation System)																																																		
FOCUS C-MAX	1.8L GASOLINE	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	PDM(Passenger's Door Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FOCUS C-MAX	1.8L GASOLINE	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	RETM(Rear Entertainment Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	RKE(Remote Keyless Entry)																																																		
FOCUS C-MAX	1.8L GASOLINE	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SYSTEM SEARCH																																																		
FOCUS C-MAX	2.0L DIESEL	PCM(PowerTrain Control Module)										V													V																												
FOCUS C-MAX	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																		
FOCUS C-MAX	2.0L DIESEL	ACM(Audio Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	BCMii(Body Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	DDM(Driver's Door Module)																																																		
FOCUS C-MAX	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																																																		
FOCUS C-MAX	2.0L DIESEL	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
FOCUS C-MAX	2.0L DIESEL	IPM-A(Image Processing Module A)																																																		
FOCUS C-MAX	2.0L DIESEL	IPM-B(Image Processing Module B)																																																		
FOCUS C-MAX	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	2.0L DIESEL	PDM(Passenger's Door Module)																																																		
FOCUS C-MAX	2.0L DIESEL	PSCM(Power Steering Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	RFA(Remote Function Actuator)																																																		
FOCUS C-MAX	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																									V																										
FOCUS C-MAX	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																		
FOCUS C-MAX	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																		
FOCUS C-MAX	2.0L GASOLINE	SYSTEM SEARCH																																																		
FOCUS C-MAX	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FOCUS C-MAX	2.0L GASOLINE	ACM(Audio Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	CDP(Compact Disc Player)																																																		
FOCUS C-MAX	2.0L GASOLINE	CMR(Camera Module Rear)																																																		
FOCUS C-MAX	2.0L GASOLINE	D_DCU(Driver Door Control Unit)																																																		
FOCUS C-MAX	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS C-MAX	2.0L GASOLINE	EPB(Electronic Parking Brake)																																																		
FOCUS C-MAX	2.0L GASOLINE	EPS(Electronic Power Steering)																																																		
FOCUS C-MAX	2.0L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	GDM(Generic Display Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	GEM(Generic Electronic Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	IC(Instrument Cluster)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
FOCUS C-MAX	2.0L GASOLINE	NAV(Navigation System)																																																		
FOCUS C-MAX	2.0L GASOLINE	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	PDM(Passenger's Door Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	RETM(Rear Entertainment Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	RKE(Remote Keyless Entry)																																																		
FOCUS C-MAX	2.0L GASOLINE	SRM(Speech Recognition Module)																																																		
FUSION	1.4L DIESEL	SYSTEM SEARCH																																																		
FUSION	1.4L DIESEL	PCM(PowerTrain Control Module)																																																		
FUSION	1.4L DIESEL	TCM(Transmission Control Module)																																																		
FUSION	1.4L DIESEL	ABS(Anti-Lock Brake System)																																																		
FUSION	1.4L DIESEL	IC(Instrument Cluster)																																																		
FUSION	1.4L DIESEL	ACM(Audio Control Module)																																																		
FUSION	1.4L DIESEL	EATC(Electronic Automatic Temperature Control)																																																		
FUSION	1.4L DIESEL	GEM(Generic Electronic Module)																																																		
FUSION	1.4L DIESEL	SRM(Speech Recognition Module)																																																		
FUSION	1.4L DIESEL	RCM(Restraint Control Module)																																																		
FUSION	1.4L DIESEL	PATS(Passive Anti Theft System)-BETA																																																		
FUSION	1.6L DIESEL	SYSTEM SEARCH																																																		
FUSION	1.6L DIESEL	PCM(PowerTrain Control Module)																																																		
FUSION	1.6L DIESEL	TCM(Transmission Control Module)																																																		
FUSION	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																		
FUSION	1.6L DIESEL	IC(Instrument Cluster)																																																		
FUSION	1.6L DIESEL	ACM(Audio Control Module)																																																		
FUSION	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)																																																		
FUSION	1.6L DIESEL	GEM(Generic Electronic Module)																																																		
FUSION	1.6L DIESEL	SRM(Speech Recognition Module)																																																		
FUSION	1.6L DIESEL	RCM(Restraint Control Module)																																																		
FUSION	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									V																									
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										V																								
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																											V	V	V	V																			
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																															V																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																															V	V	V	V	V	V	V												
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)					V	V			V																																									
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																									V																									
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										V																								
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																											V	V	V	V																				
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																															V																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																															V	V	V	V	V	V	V												
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)									V																																								
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																								V																									
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									V																								
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										V	V	V	V																					
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																														V																			
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																															V	V	V	V	V	V	V												
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																								V																									
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									V																								
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										V	V	V	V																					
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																															V	V	V	V	V	V	V												
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																					V	V											
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																								V																								
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									V																								
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										V	V	V	V																				
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																														V																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																															V	V	V	V	V	V	V												
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)																							V																											
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TCM(Transmission Control Module)																																								V	V	V	V	V					
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																										V																								
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																											V	V	V	V																				
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CDP(Compact Disc Player)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DABM(Digital Audio Broadcast Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver's Seat Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	NAV(Navigation System)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PBM(Parking Brake Control Module)																															V	V	V	V	V	V	V													
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)															V																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																																															V	V		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																																															V	V
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																																																
F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																																																
F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																																																
F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																																																
F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																																																
F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																																													V	V		
F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																																																
F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																																																
F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																																																
F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																																															V	V
F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																																																
F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																																																
F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																																																
F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																																																
F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																																																
F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																																																
F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																																																
F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																																																
F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																																																
F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																																																
F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																																																
F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																																																
F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																																																
F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																																																
F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)														V																																	
F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																																															
F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																																															
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																																															
F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																																															
F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																																															
F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																																															
F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																																															
F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																																															
F150	4.6L(BETA)	2V	2009 ~	GEMS/BJ(Generic Electronic Module/Smart Junction Box)																																															
F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																																															
F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																																															
F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																																															
F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																																													V	V
F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																																															
F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																																															
F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																																															
F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																																													V		
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																																													V		
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																																															
F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																																															
F150	4.6L(BETA)	3V	SYSTEM SEARCH																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)															V																																		
F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																																																	
F150	4.6L(BETA)	3V	ACM(Audio Control Module)																																																	
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																																																	
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																																																	
F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																																																	
F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																																																	
F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																																																	
F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																																																	
F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																																																	
F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																																																	
F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	4.6L(BETA)	3V	IC(Instrument Cluster)																																																	
F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																																																	
F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																																																V	V
F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																																																	
F150	4.6L(BETA)	3V	PRB(Power Running Board)																																																	
F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																																																	
F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																																																	
F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																																																	
F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																																																	
F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																																																	
F150	5.0L	TiVCT	SYSTEM SEARCH																																																	
F150	5.0L	TiVCT	PCM(Powertrain Control Module)															V																																		
F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																																																	
F150	5.0L	TiVCT	ACM(Audio Control Module)																																																	
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																																																	
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																																																	
F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																																																	
F150	5.0L	TiVCT	DSM(Driver's Seat Module)																																																	
F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																																																	
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																																																	
F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																																																	
F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																																																	
F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	5.0L	TiVCT	IC(Instrument Cluster)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																																																
F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																																															V	V
F150	5.0L	TiVCT	PAM(Parking Aid Module)																																																
F150	5.0L	TiVCT	PAM(Parking Aid Module)																																																
F150	5.0L	TiVCT	PRB(Power Running Board)																																																
F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																																																
F150	5.0L	TiVCT	RCM(Restraint Control Module)																																																
F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																																																
F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																																																
F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																																																
F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																																																
F150	5.0L	TiVCT	TCM(Transmission Control Module)																																																
F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																																																
F150	5.4L	3V	2009 ~	SYSTEM SEARCH																																															
F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)														V																																	
F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																																																
F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																																																
F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																																																
F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																																																
F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																																																
F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																																																
F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																																																
F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																																																
F150	5.4L	3V	2009 ~	GEMS/JB(Generic Electronic Module/Smart Junction Box)																																																
F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																																																
F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																																																
F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																																																
F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																																																
F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																																															V	V
F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																																																
F150	5.4L	3V	2009 ~	PRB(Power Running Board)																																																
F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																																																
F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																																																
F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																																																
F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																																																
F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																																																
F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																																																
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																																															
F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																																															
F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																																															
F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																																															
F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																															
F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																																															
F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																																															
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																																														V	
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																																														V	
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																																															
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																																															
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																																															
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																																															
F150	6.2L(BETA)	2V	SYSTEM SEARCH																																															
F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																																															
F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																																															
F150	6.2L(BETA)	2V	ACM(Audio Control Module)																																															
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																																															
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																																															
F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																																															
F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																																															
F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																																															
F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																																															
F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																															
F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																																															
F150	6.2L(BETA)	2V	IC(Instrument Cluster)																																															
F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																																															
F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																																														V	V
F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																																															
F150	6.2L(BETA)	2V	PRB(Power Running Board)																																															
F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																																															
F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																																															
F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																																															
F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																																															
F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																																															
F150	Other	2004 ~ 2008	SYSTEM SEARCH																																															
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																																															
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																																															
F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																																															
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																																															
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																																															
F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																																																
F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																																																
F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																																
F150	Other	2004 ~ 2008	IC(Instrument Cluster)																																																
F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																																																
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																																															V	
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																																															V	
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																																																
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																																																
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																																																
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																																																
F250	7.3L	SYSTEM SEARCH																																																	
F250	7.3L	PCM(PowerTrain Control Module)																																																	
F250	7.3L	ABS(Anti-Lock Brake System)																																																	
F250	7.3L	ECS(Electronic Crash Sensor)																																																	
F250	7.3L	GEM(Generic Electronic Module)																																																	
F250	6.2L	SYSTEM SEARCH																																																	
F250	6.2L	PCM(Powertrain Control Module)																V																																	
F250	6.2L	ABS(Anti-Lock Brake System)																																																	
F250	6.2L	ACM(Audio Control Module)																																																	
F250	6.2L	APIM(Accessory Protocol Interface Module)																																																	
F250	6.2L	BCMii(Body Control Module)																																																	
F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																																																	
F250	6.2L	DSM(Driver Seat Module)																																																	
F250	6.2L	GPSM(Global Positioning System Module)																																																	
F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																																																	
F250	6.2L	IPC(Instrument Panel Control Module)																																																	
F250	6.2L	PAM(Parking Aid Module)																																																	
F250	6.2L	RCM(Restraint Control Module)																																																	
F250	6.2L	SCCM(Streering Colume Control Module)																																																	
F250	6.2L	TBC(Trailer Brake Control Module)																																																	
F250	6.2L	TCCM(Transfer Case Control Module)																																																	
F250	6.2L	TPM(Tire Pressure Monitor)																																																	
F250	6.0L Diesel	SYSTEM SEARCH																																																	
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																	
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																	
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																	
F250	6.0L Diesel	ABS(Anti-Lock Brake System)																																																	
F250	6.0L Diesel	GEM(Generic Electronic Module)																																																	
F250	6.0L Diesel	HEC(Hybrid Electrical Cluster)																																																	
F250	6.0L Diesel	OTC(Overhead Trip Computer)																																																	
F250	6.0L Diesel	PAM(Parking Aid Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
F250	6.0L Diesel	PATS(Passive Anti Theft System)																																																	
F250	6.0L Diesel	RCM(Restraint Control Module)																																																	
F250	6.0L Diesel	TCM(Transmission Control Module)																																																	
F250	6.0L Diesel	TCM(Transmission Control Module)																																																	
F250	6.0L Diesel	TCM(Transmission Control Module)																																																	
F250	6.0L Diesel	VSM(Vehicle Security Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																																														V		
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																																															
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																
KA	KA	SYSTEM SEARCH																																																	
KA	KA	PCM(PowerTrain Control Module)																																																	
KA	KA	ABS(Anti-Lock Brake System)																																																	
KA	KA	RCM(Restraint Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)															V																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																																															V	V
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																
KUGA	2.0L DIESEL	SYSTEM SEARCH																																																	
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)					V																																												
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)							V			V					V																																			
KUGA	2.0L DIESEL	TCM(Transmission Control Module)																																																	
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)																		V																															
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
KUGA	2.0L DIESEL	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
KUGA	2.0L DIESEL	ACM(Audio Control Module)																																																	
KUGA	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
KUGA	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																																																	
KUGA	2.0L DIESEL	AWD(All Wheel Drive Module)																																																	
KUGA	2.0L DIESEL	BCMii(Body Control Module)																																																	
KUGA	2.0L DIESEL	CCMii(Cruise Control Module)																																																	
KUGA	2.0L DIESEL	CMR(Camera Module Rear)																																																	
KUGA	2.0L DIESEL	D_DCU(Driver Door Control Unit)																																																	
KUGA	2.0L DIESEL	DDM(Driver's Door Module)																																																	
KUGA	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
KUGA	2.0L DIESEL	EPS(Electronic Power Steering)																																																	
KUGA	2.0L DIESEL	FDSM(Front Distance Sensing Module)																																																	
KUGA	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																																																	
KUGA	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
KUGA	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
KUGA	2.0L DIESEL	GPSM(Global Positioning System Module)																																																	
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)																																																	
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)																																																	
KUGA	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
KUGA	2.0L DIESEL	IPM-A(Image Processing Module A)																																																	
KUGA	2.0L DIESEL	IPM-B(Image Processing Module B)																																																	
KUGA	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																	
KUGA	2.0L DIESEL	IC(Instrument Cluster)																																																	
KUGA	2.0L DIESEL	PAM(Parking Aid Module)																																																	
KUGA	2.0L DIESEL	PAM(Parking Aid Module)																																																	
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)																																																	
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)																																																	
KUGA	2.0L DIESEL	PSCM(Power Steering Control Module)																																																	
KUGA	2.0L DIESEL	RCM(Restraint Control Module)																																																	
KUGA	2.0L DIESEL	RCM(Restraint Control Module)																																																	
KUGA	2.0L DIESEL	RFA(Remote Function Actuator)																																																	
KUGA	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																	
KUGA	2.0L DIESEL	RETM(Rear Entertainment Module)																																																	
KUGA	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																	
KUGA	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																	
KUGA	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																	
KUGA	2.0L DIESEL	SRM(Speech Recognition Module)																																																	
KUGA	2.0L DIESEL	TRM(Trailer Module)																																																	
KUGA	2.5L GASOLINE	SYSTEM SEARCH																																																	
KUGA	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
KUGA	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
KUGA	2.5L GASOLINE	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
KUGA	2.5L GASOLINE	AWD(All Wheel Drive Module)																																																	
KUGA	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
KUGA	2.5L GASOLINE	D_DCU(Driver Door Control Unit)																																																	
KUGA	2.5L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
KUGA	2.5L GASOLINE	EPS(Electronic Power Steering)																																																	
KUGA	2.5L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																	
KUGA	2.5L GASOLINE	GEM(Generic Electronic Module)																																																	
KUGA	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
KUGA	2.5L GASOLINE	IC(Instrument Cluster)																																																	
KUGA	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
KUGA	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
KUGA	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
KUGA	2.5L GASOLINE	RETM(Rear Entertainment Module)																																																	
KUGA	2.5L GASOLINE	RKE(Remote Keyless Entry)																																																	
KUGA	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
KUGA	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																							V																									
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																								V																								
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																									V	V	V	V																				
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																													V																			
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																														V	V	V	V	V	V	V												
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SDD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)					V			V	V	V	V	V																																					
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	CCMii(Cruise Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DCDC(DC to DC Convertal Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DDM(Driver's Door Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSM(Driver Seat Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSP(Digital Signal Processing Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCIM(Front Controls Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FDSM(Front Distance Sensing Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCDIM(Front Control/Display Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GPSM(Global Positioning System Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GWM(Gateway Module A)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HCM(Headlamp Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HSWM(Heated Steering Wheel Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HUD(Head Up Display)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPC(Instrument Panel Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PAM(Parking Aid Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PDM(Passenger's Door Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PSCM(Power Steering Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RACM(Rear Audio Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RCM(Restraint Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RTM(Radio Transceiver Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCCM(Streering Colume Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-E(Seat Control Module E)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-G(Seat Control Module G)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-H(Seat Control Module H)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SDD-L(Side Obstacle Detection Control Module Left)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SDD-R(Side Obstacle Detection Control Module Right)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TRM(Trailer Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)					V			V	V	V	V	V																																				
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DCDC(DC to DC Convertal Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver Seat Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSP(Digital Signal Processing Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GWM(Gateway Module A)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HSWM(Heated Steering Wheel Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HUD(Head Up Display)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RACM(Rear Audio Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RTM(Radio Transceiver Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCCM(Streering Colume Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-E(Seat Control Module E)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-G(Seat Control Module G)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-H(Seat Control Module H)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)				V	V			V																																									
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																								V																								
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									V																								
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																									V	V	V	V																			
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																													V																			
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																														V	V	V	V	V	V	V												
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																								V																							
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									V																							
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																									V	V	V	V																			
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																													V																			
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																														V	V	V	V	V	V	V												
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																															
MONDEO	2012 MY	2.0L DIESEL	SYSTEM SEARCH																																																
MONDEO	2012 MY	2.0L DIESEL	PCM(PowerTrain Control Module)						V			V					V									V																										
MONDEO	2012 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																										V																							
MONDEO	2012 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	BCMii(Body Control Module)																											V	V	V	V																			
MONDEO	2012 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2012 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2012 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																
MONDEO	2012 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	2.0L DIESEL	IPM-A(Image Processing Module A)																																																
MONDEO	2012 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2012 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																															V	V	V	V	V	V	V												
MONDEO	2012 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2012 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2012 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2012 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2012 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2012 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2012 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																
MONDEO	2012 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																
MONDEO	2012 MY	2.0L DIESEL	TCM(Transmission Control Module)																								V																								
MONDEO	2012 MY	2.0L DIESEL	TRM(Trailer Module)																																																
MONDEO	2012 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)				V	V			V																																								
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																							V																								
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									V																							
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																									V	V	V	V																			
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																													V																			
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																														V	V	V	V	V	V	V												
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																								V																							
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									V																							
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																									V	V	V	V																			
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																													V																			
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																														V	V	V	V	V	V	V												
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																															
MONDEO	2011 MY	2.0L DIESEL	SYSTEM SEARCH																																																
MONDEO	2011 MY	2.0L DIESEL	PCM(PowerTrain Control Module)						V			V					V									V																										
MONDEO	2011 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																										V																							
MONDEO	2011 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	BCMii(Body Control Module)																											V	V	V	V																			
MONDEO	2011 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																
MONDEO	2011 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	2.0L DIESEL	IPM-A(Image Processing Module A)																																																
MONDEO	2011 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																															V	V	V	V	V	V	V												
MONDEO	2011 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2011 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2011 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2011 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2011 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2011 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																
MONDEO	2011 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																
MONDEO	2011 MY	2.0L DIESEL	TCM(Transmission Control Module)																								V																								
MONDEO	2011 MY	2.0L DIESEL	TRM(Trailer Module)																																																
MONDEO	2011 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2011 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																										V																							
MONDEO	2011 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2011 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																														V	V	V	V	V	V													
MONDEO	2011 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2011 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																									V	V						
MONDEO	2011 MY	2.3L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																
MONDEO	2011 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2011 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2011 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2011 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2011 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																							V	V	V	V	V					
MONDEO	2011 MY	2.5L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																
MONDEO	2011 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2010 MY	2.0L	DIESEL	SYSTEM SEARCH																																															
MONDEO	2010 MY	2.0L	DIESEL	PCM(PowerTrain Control Module)		V	V																																												
MONDEO	2010 MY	2.0L	DIESEL	ABS(Anti-Lock Brake System)																							V																								
MONDEO	2010 MY	2.0L	DIESEL	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	BCMii(Body Control Module)																									V	V	V	V																			
MONDEO	2010 MY	2.0L	DIESEL	CCMii(Cruise Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	CMR(Camera Module Rear)																																															
MONDEO	2010 MY	2.0L	DIESEL	DDM(Driver's Door Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	DSM(Driver's Seat Module)																													V																		
MONDEO	2010 MY	2.0L	DIESEL	HCM(Headlamp Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2010 MY	2.0L	DIESEL	IPC(Instrument Panel Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PAM(Parking Aid Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PBM(Parking Brake Control Module)																														V	V	V	V	V	V												
MONDEO	2010 MY	2.0L	DIESEL	PDM(Passenger's Door Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PSCM(Power Steering Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	RCM(Restraint Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	RFA(Remote Function Actuator)																																															
MONDEO	2010 MY	2.0L	DIESEL	SASM(Steering Angle Sensor Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	SRM(Speech Recognition Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	TCM(Transmission Control Module)																																							V	V	V	V	V				
MONDEO	2010 MY	2.0L	DIESEL	TRM(Trailer Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	VDM(Vehicle Dynamic Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																							V																								
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																							V																								
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																									V	V	V	V																			
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																														V	V	V	V	V	V	V											
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2010 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																									V																							
MONDEO	2010 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	BCMii(Body Control Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																															
MONDEO	2010 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2010 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																															V	V	V	V	V	V												
MONDEO	2010 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																															
MONDEO	2010 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																									V	V						
MONDEO	2010 MY	2.3L GASOLINE	TRM(Trailer Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																															
MONDEO	2010 MY	2.5L GASOLINE	SYSTEM SEARCH																																															
MONDEO	2010 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																															
MONDEO	2010 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	BCMii(Body Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2010 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2010 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2010 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2010 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																							V	V	V	V	V					
MONDEO	2010 MY	2.5L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																								V																								
MONDEO	2009 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																									V	V	V	V																				
MONDEO	2009 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																													V																			
MONDEO	2009 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																														V	V	V	V	V	V													
MONDEO	2009 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2009 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2009 MY	1.8L DIESEL	PCM(PowerTrain Control Module)			V	V																																													
MONDEO	2009 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																									V																								
MONDEO	2009 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	BCMii(Body Control Module)																										V	V	V	V																				
MONDEO	2009 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2009 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	DSM(Driver's Seat Module)																														V																			
MONDEO	2009 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2009 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																															V	V	V	V	V	V													
MONDEO	2009 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																	
MONDEO	2009 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	TRM(Trailer Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)			V	V																																													
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																																								V	V	V	V	V					
MONDEO	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																									V																								
MONDEO	2009 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																										V	V	V	V																				
MONDEO	2009 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	DSM(Driver's Seat Module)																														V																			
MONDEO	2009 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2009 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																															V	V	V	V	V	V													
MONDEO	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2009 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	2.0L DIESEL	TRM(Trailer Module)																																																
MONDEO	2009 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2009 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																									V																							
MONDEO	2009 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																														V	V	V	V	V	V													
MONDEO	2009 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																										V	V					
MONDEO	2009 MY	2.3L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																
MONDEO	2009 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2009 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2009 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2009 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2009 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																								V	V	V	V	V				
MONDEO	2009 MY	2.5L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																								V																								
MONDEO	2008 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																									V	V	V	V																				
MONDEO	2008 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																													V																			
MONDEO	2008 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																														V	V	V	V	V	V													
MONDEO	2008 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																
MONDEO	2008 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	2008 MY	1.8L DIESEL	PCM(PowerTrain Control Module)			V	V																																													
MONDEO	2008 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																									V																								
MONDEO	2008 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2008 MY	1.8L DIESEL	BCMii(Body Control Module)																										V	V	V	V																				
MONDEO	2008 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2008 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2008 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2008 MY	1.8L DIESEL	DSM(Driver's Seat Module)																														V																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2008 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																																
MONDEO	2008 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2008 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2008 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2008 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																														V	V	V	V	V	V													
MONDEO	2008 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2008 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																
MONDEO	2008 MY	1.8L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2008 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2008 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2008 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2008 MY	1.8L DIESEL	TRM(Trailer Module)																																																
MONDEO	2008 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2008 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																									V																							
MONDEO	2008 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2008 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2008 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																														V	V	V	V	V	V													
MONDEO	2008 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2008 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																										V	V					
MONDEO	2008 MY	2.3L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																
MONDEO	2008 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2008 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2008 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2008 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2008 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2008 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2008 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2008 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																							V	V	V	V	V					
MONDEO	2008 MY	2.5L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																
MONDEO	2008 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																								V																							
MONDEO	2007 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																									V	V	V	V																			
MONDEO	2007 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																													V																		
MONDEO	2007 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																														V	V	V	V	V	V											
MONDEO	2007 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2007 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	2007 MY	1.8L DIESEL	PCM(PowerTrain Control Module)			V	V																																												
MONDEO	2007 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																									V																							
MONDEO	2007 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	BCMii(Body Control Module)																										V	V	V	V																			
MONDEO	2007 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2007 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2007 MY	1.8L DIESEL	DSM(Driver's Seat Module)																														V																		
MONDEO	2007 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2007 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2007 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																															V	V	V	V	V	V												
MONDEO	2007 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2007 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2007 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2007 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2007 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2007 MY	1.8L DIESEL	TRM(Trailer Module)																																																
MONDEO	2007 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2007 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																									V																							
MONDEO	2007 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2007 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2007 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																															V	V	V	V	V	V												
MONDEO	2007 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2007 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2007 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																										V	V					
MONDEO	2007 MY	2.3L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																
MONDEO	2007 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2007 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2007 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2007 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2007 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2007 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2007 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																								V	V	V	V	V				
MONDEO	2007 MY	2.5L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																
MONDEO	2007 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																
MONDEO	2003 MY	2.0L DIESEL	SYSTEM SEARCH																																																
MONDEO	2003 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2003 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2003 MY	2.0L DIESEL	CSM(Central Security Module)																																																
MONDEO	2003 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																
MONDEO	2003 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																
MONDEO	2003 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2003 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																
MONDEO	2003 MY	2.0L DIESEL	ACM(Audio Control Module)																																																
MONDEO	2003 MY	2.0L DIESEL	CDP(Compact Disc Player)																																																
MONDEO	2003 MY	2.0L DIESEL	GDM(Generic Display Module)																																																
MONDEO	2003 MY	2.0L DIESEL	NAV(Navigation System)																																																
MONDEO	2003 MY	2.0L DIESEL	RETM(Rear Entertainment Module)																																																
MONDEO	2003 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2003 MY	2.0L DIESEL	ICU(Injector Control Unit)																																																
MONDEO	2003 MY	2.0L DIESEL	PATS(Passive Anti Theft System)																																																
MONDEO	2002 MY	2.0L DIESEL	SYSTEM SEARCH																																																
MONDEO	2002 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2002 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2002 MY	2.0L DIESEL	CSM(Central Security Module)																																																
MONDEO	2002 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																
MONDEO	2002 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																
MONDEO	2002 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2002 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																
MONDEO	2002 MY	2.0L DIESEL	ACM(Audio Control Module)																																																
MONDEO	2002 MY	2.0L DIESEL	CDP(Compact Disc Player)																																																
MONDEO	2002 MY	2.0L DIESEL	GDM(Generic Display Module)																																																
MONDEO	2002 MY	2.0L DIESEL	NAV(Navigation System)																																																
MONDEO	2002 MY	2.0L DIESEL	RETM(Rear Entertainment Module)																																																
MONDEO	2002 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2002 MY	2.0L DIESEL	ICU(Injector Control Unit)																																																
MONDEO	2002 MY	2.0L DIESEL	PATS(Passive Anti Theft System)																																																
MONDEO	2002 MY	2.0L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2002 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2002 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2002 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																
MONDEO	2002 MY	2.0L GASOLINE	GEM(Generic Electronic Module)																																																
MONDEO	2002 MY	2.0L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2002 MY	2.0L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2001 MY	2.0L DIESEL	SYSTEM SEARCH																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	2001 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2001 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																
MONDEO	2001 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																
MONDEO	2001 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																
MONDEO	2001 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																
MONDEO	2001 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																
MONDEO	2001 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																
MONDEO	2001 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																
MONDEO	2001 MY	2.0L DIESEL	ACM(Audio Control Module)																																																
MONDEO	2001 MY	2.0L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2001 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2001 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2001 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																
MONDEO	2001 MY	2.0L GASOLINE	GEM(Generic Electronic Module)																																																
MONDEO	2001 MY	2.0L GASOLINE	HCM(Headlamp Control Module)																																																
MONDEO	2001 MY	2.0L GASOLINE	RCM(Restraint Control Module)																																																
MONDEO	2000 MY	1.8L	SYSTEM SEARCH																																																
MONDEO	2000 MY	1.8L	PCM(PowerTrain Control Module)																																																
MONDEO	2000 MY	1.8L	ABS(Anti-Lock Brake System)																																																
MONDEO	2000 MY	1.8L	CSM(Central Security Module)																																																
MONDEO	2000 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	2000 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2000 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	2000 MY	1.8L DIESEL	CSM(Central Security Module)																																																
MONDEO	2000 MY	1.8L DIESEL	Passive Antitheft																																																
MONDEO	2000 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																
MONDEO	2000 MY	2.0L	SYSTEM SEARCH																																																
MONDEO	2000 MY	2.0L	PCM(PowerTrain Control Module)																																																
MONDEO	2000 MY	2.0L	ABS(Anti-Lock Brake System)																																																
MONDEO	2000 MY	2.0L	CSM(Central Security Module)																																																
MONDEO	2000 MY	2.5L	SYSTEM SEARCH																																																
MONDEO	2000 MY	2.5L	PCM(PowerTrain Control Module)																																																
MONDEO	2000 MY	2.5L	ABS(Anti-Lock Brake System)																																																
MONDEO	2000 MY	2.5L	CSM(Central Security Module)																																																
MONDEO	1999 MY	1.8L	SYSTEM SEARCH																																																
MONDEO	1999 MY	1.8L	PCM(PowerTrain Control Module)																																																
MONDEO	1999 MY	1.8L	ABS(Anti-Lock Brake System)																																																
MONDEO	1999 MY	1.8L	CSM(Central Security Module)																																																
MONDEO	1999 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	1999 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MONDEO	1999 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	1999 MY	1.8L DIESEL	CSM(Central Security Module)																																																
MONDEO	1999 MY	1.8L DIESEL	Passive Antitheft																																																
MONDEO	1999 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																
MONDEO	1999 MY	2.0L	SYSTEM SEARCH																																																
MONDEO	1999 MY	2.0L	PCM(PowerTrain Control Module)																																																
MONDEO	1999 MY	2.0L	ABS(Anti-Lock Brake System)																																																
MONDEO	1999 MY	2.0L	CSM(Central Security Module)																																																
MONDEO	1999 MY	2.5L	SYSTEM SEARCH																																																
MONDEO	1999 MY	2.5L	PCM(PowerTrain Control Module)																																																
MONDEO	1999 MY	2.5L	ABS(Anti-Lock Brake System)																																																
MONDEO	1999 MY	2.5L	CSM(Central Security Module)																																																
MONDEO	1998 MY	1.8L	SYSTEM SEARCH																																																
MONDEO	1998 MY	1.8L	PCM(PowerTrain Control Module)																																																
MONDEO	1998 MY	1.8L	ABS(Anti-Lock Brake System)																																																
MONDEO	1998 MY	1.8L	CSM(Central Security Module)																																																
MONDEO	1998 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	1998 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	1998 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	1998 MY	1.8L DIESEL	CSM(Central Security Module)																																																
MONDEO	1998 MY	1.8L DIESEL	Passive Antitheft																																																
MONDEO	1998 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																
MONDEO	1998 MY	2.0L	SYSTEM SEARCH																																																
MONDEO	1998 MY	2.0L	PCM(PowerTrain Control Module)																																																
MONDEO	1998 MY	2.0L	ABS(Anti-Lock Brake System)																																																
MONDEO	1998 MY	2.0L	CSM(Central Security Module)																																																
MONDEO	1998 MY	2.5L	SYSTEM SEARCH																																																
MONDEO	1998 MY	2.5L	PCM(PowerTrain Control Module)																																																
MONDEO	1998 MY	2.5L	ABS(Anti-Lock Brake System)																																																
MONDEO	1998 MY	2.5L	CSM(Central Security Module)																																																
MONDEO	1997 MY	1.8L	PCM(PowerTrain Control Module)																																																
MONDEO	1997 MY	1.8L	ABS(Anti-Lock Brake System)																																																
MONDEO	1997 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	1997 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	1997 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																
MONDEO	1997 MY	1.8L DIESEL	Passive Antitheft																																																
MONDEO	1997 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																
MONDEO	1997 MY	2.0L	PCM(PowerTrain Control Module)																																																
MONDEO	1997 MY	2.0L	ABS(Anti-Lock Brake System)																																																
MONDEO	1997 MY	2.5L	PCM(PowerTrain Control Module)																																																
MONDEO	1997 MY	2.5L	ABS(Anti-Lock Brake System)																																																
MOUNTAINEER	2010 MY	4.6L	SYSTEM SEARCH																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MOUNTAINEER	2010 MY	4.6L	PCM(Powertrain Control Module)																																																
MOUNTAINEER	2010 MY	4.6L	TCM(Transmission Control Module)																																																
MOUNTAINEER	2010 MY	4.6L	4X4(4x4 Control Module)																																																
MOUNTAINEER	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																
MOUNTAINEER	2010 MY	4.6L	ACM(Audio Control Module)																																																
MOUNTAINEER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																
MOUNTAINEER	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																
MOUNTAINEER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																
MOUNTAINEER	2010 MY	4.6L	DSM(Driver's Seat Module)																																																
MOUNTAINEER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
MOUNTAINEER	2010 MY	4.6L	IC(Instrument Cluster)																																																
MOUNTAINEER	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																
MOUNTAINEER	2010 MY	4.6L	PAM(Parking Aid Module)																																																
MOUNTAINEER	2010 MY	4.6L	PRB(Power Running Board)																																																
MOUNTAINEER	2010 MY	4.6L	RCM(Restraint Control Module)																																																
MOUNTAINEER	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																
MOUNTAINEER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
MOUNTAINEER	2009 MY	4.6L	SYSTEM SEARCH																																																
MOUNTAINEER	2009 MY	4.6L	PCM(Powertrain Control Module)																																																
MOUNTAINEER	2009 MY	4.6L	TCM(Transmission Control Module)																																																
MOUNTAINEER	2009 MY	4.6L	4X4(4x4 Control Module)																																																
MOUNTAINEER	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																
MOUNTAINEER	2009 MY	4.6L	ACM(Audio Control Module)																																																
MOUNTAINEER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																
MOUNTAINEER	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																
MOUNTAINEER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																
MOUNTAINEER	2009 MY	4.6L	DSM(Driver's Seat Module)																																																
MOUNTAINEER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
MOUNTAINEER	2009 MY	4.6L	IC(Instrument Cluster)																																																
MOUNTAINEER	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																
MOUNTAINEER	2009 MY	4.6L	PAM(Parking Aid Module)																																																
MOUNTAINEER	2009 MY	4.6L	PRB(Power Running Board)																																																
MOUNTAINEER	2009 MY	4.6L	RCM(Restraint Control Module)																																																
MOUNTAINEER	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																
MOUNTAINEER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																
MUSTANG	4.0L V6 SOHC			SYSTEM SEARCH																																																
MUSTANG	4.0L V6 SOHC			PCM(Powertrain Control Module)																																																
MUSTANG	4.0L V6 SOHC			ABS(Anti-Lock Brake System)																																																
MUSTANG	4.0L V6 SOHC			ACM(Audio Control Module)																																																
MUSTANG	4.0L V6 SOHC			APIM(Accessory Protocol Interface Module)																																																
MUSTANG	4.0L V6 SOHC			GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
MUSTANG	4.0L V6 SOHC			RCM(Restraint Control Module)																																															V	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
MUSTANG	4.0L V6 SOHC			SDARS(Satellite Digital Audio Receiver System)																																																
MUSTANG	4.0L V6 SOHC			IC(Instrument Cluster)																																																
TAURUS	2011 MY	3.5L	SYSTEM SEARCH																																																	
TAURUS	2011 MY	3.5L	PCM(PowerTrain Control Module)																																																	
TAURUS	2011 MY	3.5L	4X4(4x4 Control Module)																																																	
TAURUS	2011 MY	3.5L	ABS(Anti-Lock Brake System)																																																	
TAURUS	2011 MY	3.5L	ACM(Audio Control Module)																																																	
TAURUS	2011 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																	
TAURUS	2011 MY	3.5L	C-CM(Cruise Control Module)																																																	
TAURUS	2011 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																	
TAURUS	2011 MY	3.5L	DDM(Driver's Door Module)																																																	
TAURUS	2011 MY	3.5L	DSM(Driver's Seat Module)																																																	
TAURUS	2011 MY	3.5L	DSP(Digital Signal Processing Module)																																																	
TAURUS	2011 MY	3.5L	FCIM(Front Controls Interface Module)																																																	
TAURUS	2011 MY	3.5L	FDIM(Front Display Interface Module)																																																	
TAURUS	2011 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
TAURUS	2011 MY	3.5L	GPSM(Global Positioning System Module)																																																	
TAURUS	2011 MY	3.5L	HCM(Headlamp Control Module)																																																	
TAURUS	2011 MY	3.5L	HCM-2(Headlamp Control Module2)																																																	
TAURUS	2011 MY	3.5L	HUD(Head Up Display)																																																	
TAURUS	2011 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																	
TAURUS	2011 MY	3.5L	ILCM(Interior Lighting Control Module)																																																	
TAURUS	2011 MY	3.5L	IPC(Instrument Panel Control Module)																																																	
TAURUS	2011 MY	3.5L	OCSM(Occupant Classification System Module)																																																	
TAURUS	2011 MY	3.5L	PAM(Parking Aid Module)																																																	
TAURUS	2011 MY	3.5L	PSCM(Power Steering Control Module)																																																	
TAURUS	2011 MY	3.5L	RCM(Restraint Control Module)																																																	
TAURUS	2011 MY	3.5L	RETM(Rear Entertainment Module)																																																	
TAURUS	2011 MY	3.5L	RFA(Remote Function Actuator)																																																	
TAURUS	2011 MY	3.5L	SASM(Steering Angle Sensor Module)																																																	
TAURUS	2011 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																	
TAURUS	2011 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																	
TAURUS	2010 MY	3.5L	SYSTEM SEARCH																																																	
TAURUS	2010 MY	3.5L	PCM(PowerTrain Control Module)																																																	
TAURUS	2010 MY	3.5L	4X4(4x4 Control Module)																																																	
TAURUS	2010 MY	3.5L	ABS(Anti-Lock Brake System)																																																	
TAURUS	2010 MY	3.5L	ACM(Audio Control Module)																																																	
TAURUS	2010 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																	
TAURUS	2010 MY	3.5L	C-CM(Cruise Control Module)																																																	
TAURUS	2010 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																	
TAURUS	2010 MY	3.5L	DDM(Driver's Door Module)																																																	
TAURUS	2010 MY	3.5L	DSM(Driver's Seat Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
TAURUS	2010 MY	3.5L	DSP(Digital Signal Processing Module)																																																
TAURUS	2010 MY	3.5L	FCIM(Front Controls Interface Module)																																																
TAURUS	2010 MY	3.5L	FDIM(Front Display Interface Module)																																																
TAURUS	2010 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
TAURUS	2010 MY	3.5L	GPSM(Global Positioning System Module)																																																
TAURUS	2010 MY	3.5L	HCM(Headlamp Control Module)																																																
TAURUS	2010 MY	3.5L	HCM-2(Headlamp Control Module2)																																																
TAURUS	2010 MY	3.5L	HUD(Head Up Display)																																																
TAURUS	2010 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																
TAURUS	2010 MY	3.5L	ILCM(Interior Lighting Control Module)																																																
TAURUS	2010 MY	3.5L	IPC(Instrument Panel Control Module)																																																
TAURUS	2010 MY	3.5L	OCSM(Occupant Classification System Module)																																																
TAURUS	2010 MY	3.5L	PAM(Parking Aid Module)																																																
TAURUS	2010 MY	3.5L	PSCM(Power Steering Control Module)																																																
TAURUS	2010 MY	3.5L	RCM(Restraint Control Module)																																																
TAURUS	2010 MY	3.5L	RETM(Rear Entertainment Module)																																																
TAURUS	2010 MY	3.5L	RFA(Remote Function Actuator)																																																
TAURUS	2010 MY	3.5L	SASM(Steering Angle Sensor Module)																																																
TAURUS	2010 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																
TAURUS	2010 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																
TAURUS	2009 MY	3.5L	SYSTEM SEARCH																																																
TAURUS	2009 MY	3.5L	PCM(PowerTrain Control Module)																																																
TAURUS	2009 MY	3.5L	4X4(4x4 Control Module)																																																
TAURUS	2009 MY	3.5L	ABS(Anti-Lock Brake System)																																																
TAURUS	2009 MY	3.5L	ACM(Audio Control Module)																																																
TAURUS	2009 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																
TAURUS	2009 MY	3.5L	C-CM(Cruise Control Module)																																																
TAURUS	2009 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																
TAURUS	2009 MY	3.5L	DDM(Driver's Door Module)																																																
TAURUS	2009 MY	3.5L	DSM(Driver's Seat Module)																																																
TAURUS	2009 MY	3.5L	DSP(Digital Signal Processing Module)																																																
TAURUS	2009 MY	3.5L	FCIM(Front Controls Interface Module)																																																
TAURUS	2009 MY	3.5L	FDIM(Front Display Interface Module)																																																
TAURUS	2009 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
TAURUS	2009 MY	3.5L	GPSM(Global Positioning System Module)																																																
TAURUS	2009 MY	3.5L	HCM(Headlamp Control Module)																																																
TAURUS	2009 MY	3.5L	HCM-2(Headlamp Control Module2)																																																
TAURUS	2009 MY	3.5L	HUD(Head Up Display)																																																
TAURUS	2009 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																
TAURUS	2009 MY	3.5L	ILCM(Interior Lighting Control Module)																																																
TAURUS	2009 MY	3.5L	IPC(Instrument Panel Control Module)																																																
TAURUS	2009 MY	3.5L	OCSM(Occupant Classification System Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
TAURUS	2009 MY	3.5L	PAM(Parking Aid Module)																																																	
TAURUS	2009 MY	3.5L	PSCM(Power Steering Control Module)																																																	
TAURUS	2009 MY	3.5L	RCM(Restraint Control Module)																																																	
TAURUS	2009 MY	3.5L	RETM(Rear Entertainment Module)																																																	
TAURUS	2009 MY	3.5L	RFA(Remote Function Actuator)																																																	
TAURUS	2009 MY	3.5L	SASM(Steering Angle Sensor Module)																																																	
TAURUS	2009 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																	
TAURUS	2009 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																	
TAURUS	2008 MY	3.5L	SYSTEM SEARCH																																																	
TAURUS	2008 MY	3.5L	PCM(PowerTrain Control Module)																																																	
TAURUS	2008 MY	3.5L	4X4(4x4 Control Module)																																																	
TAURUS	2008 MY	3.5L	ABS(Anti-Lock Brake System)																																																	
TAURUS	2008 MY	3.5L	ACM(Audio Control Module)																																																	
TAURUS	2008 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																	
TAURUS	2008 MY	3.5L	C-CM(Cruise Control Module)																																																	
TAURUS	2008 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																	
TAURUS	2008 MY	3.5L	DDM(Driver's Door Module)																																																	
TAURUS	2008 MY	3.5L	DSM(Driver's Seat Module)																																																	
TAURUS	2008 MY	3.5L	DSP(Digital Signal Processing Module)																																																	
TAURUS	2008 MY	3.5L	FCIM(Front Controls Interface Module)																																																	
TAURUS	2008 MY	3.5L	FDIM(Front Display Interface Module)																																																	
TAURUS	2008 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
TAURUS	2008 MY	3.5L	GPSM(Global Positioning System Module)																																																	
TAURUS	2008 MY	3.5L	HCM(Headlamp Control Module)																																																	
TAURUS	2008 MY	3.5L	HCM-2(Headlamp Control Module2)																																																	
TAURUS	2008 MY	3.5L	HUD(Head Up Display)																																																	
TAURUS	2008 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																	
TAURUS	2008 MY	3.5L	ILCM(Interior Lighting Control Module)																																																	
TAURUS	2008 MY	3.5L	IPC(Instrument Panel Control Module)																																																	
TAURUS	2008 MY	3.5L	OCSM(Occupant Classification System Module)																																																	
TAURUS	2008 MY	3.5L	PAM(Parking Aid Module)																																																	
TAURUS	2008 MY	3.5L	PSCM(Power Steering Control Module)																																																	
TAURUS	2008 MY	3.5L	RCM(Restraint Control Module)																																																	
TAURUS	2008 MY	3.5L	RETM(Rear Entertainment Module)																																																	
TAURUS	2008 MY	3.5L	RFA(Remote Function Actuator)																																																	
TAURUS	2008 MY	3.5L	SASM(Steering Angle Sensor Module)																																																	
TAURUS	2008 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																	
TAURUS	2008 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																	
TAURUS	1998 MY	SYSTEM SEARCH																																																		
TAURUS	1998 MY	PCM(PowerTrain Control Module)																																																		
TAURUS	1998 MY	ABS(Anti-Lock Brake System)																																																		
TAURUS	1998 MY	RCM(Restraint Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
TAURUS	1998 MY	RIM(Remote Immobilizer Module)																																																	
TAURUS	1997 MY	SYSTEM SEARCH																																																	
TAURUS	1997 MY	PCM(PowerTrain Control Module)																																																	
TAURUS	1997 MY	ABS(Anti-Lock Brake System)																																																	
TAURUS	1997 MY	RCM(Restraint Control Module)																																																	
TAURUS	1997 MY	RIM(Remote Immobilizer Module)																																																	
TAURUS	1996 MY	SYSTEM SEARCH																																																	
TAURUS	1996 MY	PCM(PowerTrain Control Module)																																																	
TAURUS	1996 MY	ABS(Anti-Lock Brake System)																																																	
TAURUS	1996 MY	RCM(Restraint Control Module)																																																	
TAURUS	1996 MY	RIM(Remote Immobilizer Module)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	SYSTEM SEARCH																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PCM(PowerTrain Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	TCM(Transmission Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ABS(Anti-Lock Brake System)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ACM(Audio Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	APIM(Accessory Protocol Interface Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	BEM(Body Electronic Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	FCIM(Front Controls Interface Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GPSM(Global Positioning System Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GWM(Gateway Module A)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	HIM(HVAC Integrated Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	IPC(Instrument Panel Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PAM(Parking Aid Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PSCM(Power Steering Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	RCM(Restraint Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	SYSTEM SEARCH																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PCM(Powertrain Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	TCM(Transmission Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	ACM(Audio Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PSCM(Power Steering Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	HIM(HVAC Integrated Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
TERRITORY	2010~	4.0L GASOLINE	SY	FDIM(Front Display Interface Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	SYSTEM SEARCH																																																
TERRITORY	2010~	2.7L DIESEL	SZ	PCM(Powertrain Control Module)					V																																											
TERRITORY	2010~	2.7L DIESEL	SZ	ABS(Anti-Lock Brake System)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	ACM(Audio Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	AWD(All Wheel Drive Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	BEM(Body Electronic Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	FDIM(Front Display Interface Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	HIM(HVAC Intergrated Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	IPC(Instrument Panel Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	PAM(Parking Aid Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	PSCM(Power Steering Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	RCM(Restraint Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	TCM(Transmission Control Module)																																																
TERRITORY	2009~2010	SYSTEM SEARCH																																																		
TERRITORY	2009~2010	PCM(PowerTrain Control Module)																																																		
TERRITORY	2009~2010	TCM(Transmission Control Module)																																																		
TERRITORY	2009~2010	ABS(Anti-Lock Brake System)																																																		
TERRITORY	2009~2010	RCM(Restraint Control Module)																																																		
TERRITORY	2009~2010	BEM(Body Electronic Module)																																																		
TERRITORY	2009~2010	IC(Instrument Cluster)																																																		
TERRITORY	2009~2010	HIM(HVAC Integrated Module)																																																		
TERRITORY	2009~2010	ACM(Audio Control Module)																																																		
TERRITORY	2005~2009	SYSTEM SEARCH																																																		
TERRITORY	2005~2009	PCM(PowerTrain Control Module)																																																		
TERRITORY	2005~2009	TCM(Transmission Control Module)																																																		
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)																																																		
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)																																																		
TERRITORY	2005~2009	RCM(Restraint Control Module)																																																		
TERRITORY	2005~2009	BEM(Body Electronic Module)																																																		
TERRITORY	2005~2009	IC(Instrument Cluster)																																																		
TERRITORY	2005~2009	HIM(HVAC Integrated Module)																																																		
TERRITORY	2005~2009	ACM(Audio Control Module)																																																		
TERRITORY	2004~2005	SYSTEM SEARCH																																																		
TERRITORY	2004~2005	PCM(PowerTrain Control Module)																																																		
TERRITORY	2004~2005	ABS(Anti-Lock Brake System)																																																		
TERRITORY	2004~2005	RCM(Restraint Control Module)																																																		
TERRITORY	2004~2005	BEM(Body Electronic Module)																																																		
TERRITORY	2004~2005	IC(Instrument Cluster)																																																		
TERRITORY	2004~2005	HIM(HVAC Integrated Module)																																																		
TERRITORY	2004~2005	HIM(HVAC Integrated Module)																																																		
TERRITORY	2004~2005	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
TERRITORY	2004~2005	PAM(Parking Aid Module)																																																		
TRANSIT	1.6L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	1.6L DIESEL	PCM(PowerTrain Control Module)						V	V			V																																								
TRANSIT	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																		
TRANSIT	1.6L DIESEL	ACM(Audio Control Module)																																																		
TRANSIT	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
TRANSIT	1.6L DIESEL	APIM(Accessory Protocol Interface Module)																																																		
TRANSIT	1.6L DIESEL	BCMii(Body Control Module)																																																		
TRANSIT	1.6L DIESEL	DDM(Driver's Door Module)																																																		
TRANSIT	1.6L DIESEL	FCIM(Front Controls Interface Module)																																																		
TRANSIT	1.6L DIESEL	FDSM(Front Distance Sensing Module)																																																		
TRANSIT	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)																																																		
TRANSIT	1.6L DIESEL	GPSM(Global Positioning System Module)																																																		
TRANSIT	1.6L DIESEL	HCM(Headlamp Control Module)																																																		
TRANSIT	1.6L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
TRANSIT	1.6L DIESEL	IPM-B(Image Processing Module B)																																																		
TRANSIT	1.6L DIESEL	IPC(Instrument Panel Control Module)																																																		
TRANSIT	1.6L DIESEL	PAM(Parking Aid Module)																																																		
TRANSIT	1.6L DIESEL	PDM(Passenger's Door Module)																																																		
TRANSIT	1.6L DIESEL	PSCM(Power Steering Control Module)																																																		
TRANSIT	1.6L DIESEL	RCM(Restraint Control Module)																																																		
TRANSIT	1.6L DIESEL	SASM(Steering Angle Sensor Module)																																																		
TRANSIT	1.6L DIESEL	TRM(Trailer Module)																																																		
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)															V																																		
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																V																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)															V																																		
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)																V																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)																																																
TRANSIT	2.0L	SYSTEM SEARCH																																																		
TRANSIT	2.0L	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.0L	PATS(Passive Anti Theft System)																																																		
TRANSIT	2.0L	ASM(Auto Shift Manual)																																																		
TRANSIT	2.0L	ABS(Anti-Lock Brake System)																																																		
TRANSIT	2.0L	HEC(Hybrid Electrical Cluster)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SYSTEM SEARCH																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PCM(PowerTrain Control Module)				V	V			V																																									
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ACM(Audio Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	APIM(Accessory Protocol Interface Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	AHCM(Auxiliary Heater Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	CCMii(Cruise Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FCDIM(Front Control/Display Interface Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	GPSM(Global Positioning System Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	HCM(Headlamp Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-A(Image Processing Module A)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-B(Image Processing Module B)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FFH(Fuel Fired Coolant Heating Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PRB(Power Running Board)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SRM(Speech Recognition Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SASM(Steering Angle Sensor Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TBC(Trailer Brake Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TRM(Trailer Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SYSTEM SEARCH																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PCM(PowerTrain Control Module)				V	V			V																																									
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ACM(Audio Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	APIM(Accessory Protocol Interface Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	AHCM(Auxiliary Heater Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	CCMii(Cruise Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FCDIM(Front Control/Display Interface Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	GPSM(Global Positioning System Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	HCM(Headlamp Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-A(Image Processing Module A)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-B(Image Processing Module B)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FFH(Fuel Fired Coolant Heating Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PRB(Power Running Board)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SRM(Speech Recognition Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SASM(Steering Angle Sensor Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TBC(Trailer Brake Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TRM(Trailer Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	SYSTEM SEARCH																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)				V											V																					V												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PATS(Passive Anti Theft System)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ASM(Auto Shift Manual)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	HEC(Hybrid Electrical Cluster)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	IPC(Instrument Panel Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	BCMii(Body Control Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	CSM(Central Security Module)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ACM(Audio Control Module)																																															
TRANSIT	2.3L DIESEL	SYSTEM SEARCH																																																	
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)						V											V																					V												
TRANSIT	2.3L DIESEL	PATS(Passive Anti Theft System)																																																	
TRANSIT	2.3L DIESEL	ASM(Auto Shift Manual)																																																	
TRANSIT	2.3L DIESEL	ABS(Anti-Lock Brake System)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
TRANSIT	2.3L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	2.3L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
TRANSIT	2.3L DIESEL	IPC(Instrument Panel Control Module)																																																	
TRANSIT	2.3L DIESEL	BCMii(Body Control Module)																																																	
TRANSIT	2.3L DIESEL	ACM(Audio Control Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	BCMii(Body Control Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)																																																
TRANSIT	2.4L DIESEL	SYSTEM SEARCH																																																	
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)						V											V																						V											
TRANSIT	2.4L DIESEL	PATS(Passive Anti Theft System)																																																	
TRANSIT	2.4L DIESEL	ASM(Auto Shift Manual)																																																	
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	2.4L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
TRANSIT	2.4L DIESEL	IPC(Instrument Panel Control Module)																																																	
TRANSIT	2.4L DIESEL	BCMii(Body Control Module)																																																	
TRANSIT	2.4L DIESEL	CSM(Central Security Module)																																																	
TRANSIT	2.4L DIESEL	ACM(Audio Control Module)																																																	
TRANSIT	2.5L DIESEL	SYSTEM SEARCH																																																	
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.5L DIESEL	PATS(Passive Anti Theft System)																																																	
TRANSIT	2.5L DIESEL	ASM(Auto Shift Manual)																																																	
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																																																
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																																																
TRANSIT	2.5L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
TRANSIT	2.5L DIESEL	CSM(Central Security Module)																																																	
TRANSIT	2.5L DIESEL	Passive Antitheft																																																	
TRANSIT	2.5L DIESEL	RIM(Remote Immobilizer Module)																																																	
TRANSIT	2.5L DIESEL	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
TRANSIT	3.2L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)						V											V																						V											
TRANSIT	3.2L DIESEL	ABS(Anti-Lock Brake System)																																																		
TRANSIT	3.2L DIESEL	ACM(Audio Control Module)																																																		
TRANSIT	3.2L DIESEL	BCMii(Body Control Module)																																																		
TRANSIT	3.2L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																		
TRANSIT	3.2L DIESEL	IPC(Instrument Panel Control Module)																																																		
TRANSIT	3.2L DIESEL	PAM(Parking Aid Module)																																																		
TRANSIT	3.2L DIESEL	RCM(Restraint Control Module)																																																		
TRANSIT	3.2L DIESEL	SRM(Speech Recognition Module)																																																		
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)															V																																	
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																V																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)															V																																	
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)																V																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)																																																
RANGER	2.2 Diesel	SYSTEM SEARCH																																																		
RANGER	2.2 Diesel	PCM(PowerTrain Control Module)						V	V			V																																									
RANGER	2.2 Diesel	ABS(Anti-Lock Brake System)																																																		
RANGER	2.2 Diesel	ACM(Audio Control Module)																																																		
RANGER	2.2 Diesel	BCMii(Body Control Module)																																																		
RANGER	2.2 Diesel	DDM(Driver's Door Module)																																																		
RANGER	2.2 Diesel	FCDIM(Front Control/Display Interface Module)																																																		
RANGER	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
RANGER	2.2 Diesel	IPC(Instrument Panel Control Module)																																																		
RANGER	2.2 Diesel	PAM(Parking Aid Module)																																																		
RANGER	2.2 Diesel	PDM(Passenger's Door Module)																																																		
RANGER	2.2 Diesel	RCM(Restraint Control Module)																																																		
RANGER	2.2 Diesel	SRM(Speech Recognition Module)																																																		
RANGER	2.2 Diesel	TBM(Tracking And Blocking Module)																																																		
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																		
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																		
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																		
RANGER	2.2 Diesel	TRM(Trailer Module)																																																		
RANGER	2.2 Diesel	PATS(Passive anti theft system)-BETA																																																		
RANGER	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																																		
RANGER	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																																																		
RANGER	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																																																		
RANGER	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																																																		
RANGER	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																																																		
RANGER	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)-BETA																																																		
RANGER	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																																		
RANGER	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																																																		
RANGER	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																																																		
RANGER	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																																																		
RANGER	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																																																		
RANGER	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)-BETA																																																		
RANGER	3.2 Diesel	~ 2015	SYSTEM SEARCH																																																	
RANGER	3.2 Diesel	~ 2015	PCM(PowerTrain Control Module)					V	V			V																																								
RANGER	3.2 Diesel	~ 2015	ABS(Anti-Lock Brake System)																																																	
RANGER	3.2 Diesel	~ 2015	ACM(Audio Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	BCMii(Body Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	DDM(Driver's Door Module)																																																	
RANGER	3.2 Diesel	~ 2015	FCDIM(Front Control/Display Interface Module)																																																	
RANGER	3.2 Diesel	~ 2015	HVAC(Heating Ventilation Air Conditioning)																																																	
RANGER	3.2 Diesel	~ 2015	IPC(Instrument Panel Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	PAM(Parking Aid Module)																																																	
RANGER	3.2 Diesel	~ 2015	PDM(Passenger's Door Module)																																																	
RANGER	3.2 Diesel	~ 2015	RCM(Restraint Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	SRM(Speech Recognition Module)																																																	
RANGER	3.2 Diesel	~ 2015	TBM(Tracking And Blocking Module)																																																	
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																	
RANGER	3.2 Diesel	~ 2015	TRM(Trailer Module)																																																	
RANGER	3.2 Diesel	~ 2015	PATS(Passive anti theft system)-BETA																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Confiuguration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
RANGER	3.2 Diesel	2015 ~	SYSTEM SEARCH																																																	
RANGER	3.2 Diesel	2015 ~	PCM(PowerTrain Control Module)					V	V			V																																								
RANGER	3.2 Diesel	2015 ~	TCM(Transmission Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	ABS(Anti-Lock Brake System)																																																	
RANGER	3.2 Diesel	2015 ~	ACM(Audio Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	APIM(Accessory Protocol Interface Module)																																																	
RANGER	3.2 Diesel	2015 ~	ATCM(All Terrain Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	BCM(Body Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	C-CM(Cruise Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	DDM(Driver's Door Module)																																																	
RANGER	3.2 Diesel	2015 ~	FCDIM(Front Control/Display Interface Module)																																																	
RANGER	3.2 Diesel	2015 ~	FCIM(Front Controls Interface Module)																																																	
RANGER	3.2 Diesel	2015 ~	GPSM(Global Positioning System Module)																																																	
RANGER	3.2 Diesel	2015 ~	GWM(Gateway Module A)																																																	
RANGER	3.2 Diesel	2015 ~	HCM(Headlamp Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	HUD(Head Up Display)																																																	
RANGER	3.2 Diesel	2015 ~	IPC(Instrument Panel Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	IPM-A(Image Processing Module A)																																																	
RANGER	3.2 Diesel	2015 ~	PAM(Parking Aid Module)																																																	
RANGER	3.2 Diesel	2015 ~	PDM(Passenger's Door Module)																																																	
RANGER	3.2 Diesel	2015 ~	PSCM(Power Steering Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	RCM(Restraint Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	RGTM(Rear Gate/Trunk Module)																																																	
RANGER	3.2 Diesel	2015 ~	RTM(Radio Transceiver Module)																																																	
RANGER	3.2 Diesel	2015 ~	SCCM(Streering Colume Control Module)																																																	
RANGER	3.2 Diesel	2015 ~	TCU(Telemetic Control Unit Module)																																																	
RANGER	3.2 Diesel	2015 ~	TRM(Trailer Module)																																																	
RANGER	2.5 Gasoline	SYSTEM SEARCH																																																		
RANGER	2.5 Gasoline	PCM(PowerTrain Control Module)																																																		
RANGER	2.5 Gasoline	ABS(Anti-Lock Brake System)																																																		
RANGER	2.5 Gasoline	ACM(Audio Control Module)																																																		
RANGER	2.5 Gasoline	BCMii(Body Control Module)																																																		
RANGER	2.5 Gasoline	DDM(Driver's Door Module)																																																		
RANGER	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																																																		
RANGER	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																																																		
RANGER	2.5 Gasoline	IPC(Instrument Panel Control Module)																																																		
RANGER	2.5 Gasoline	PAM(Parking Aid Module)																																																		
RANGER	2.5 Gasoline	PDM(Passenger's Door Module)																																																		
RANGER	2.5 Gasoline	RCM(Restraint Control Module)																																																		
RANGER	2.5 Gasoline	SRM(Speech Recognition Module)																																																		
RANGER	2.5 Gasoline	TBM(Tracking And Blocking Module)																																																		
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																		
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																		
RANGER	2.5 Gasoline	TRM(Trailer Module)																																																		
RANGER	2.5 Gasoline	PATS(Passive anti theft system)-BETA																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	MC(Message Center)																																																		
BETA-TEST	FOCUS-1.6L Zetec Rocam	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CMR(Camera Module Rear)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	D_DCU(Driver Door Control Unit)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EPS(Electronic Power Steering)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RCM(Restraint Control Module)																							V																											
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GDM(Generic Display Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	NAV(Navigation System)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RL_DCU(Rear Left Door Control Unit)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RR_DCU(Rear Right Door Control Unit)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)																																																		
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	TCM(Transmission Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PCM(PowerTrain Control Module)			V	V	V																																													
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CMR(Camera Module Rear)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	D_DCU(Driver Door Control Unit)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EPS(Electronic Power Steering)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FACM(Fuel Additive Control Module)								V	V																																									
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EPS(Electronic Power Steering)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GDM(Generic Display Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	NAV(Navigation System)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SRM(Speech Recognition Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	TCM(Transmission Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ABS(Anti-Lock Brake System)																				V	V	V																												
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EPS(Electronic Power Steering)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GDM(Generic Display Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	NAV(Navigation System)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RL_DCU(Rear Left Door Control Unit)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RR_DCU(Rear Right Door Control Unit)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SRM(Speech Recognition Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PCM(Powertrain Control Module)			V																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ABS(Anti-Lock Brake System)																		V	V																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	D_DCU(Driver Door Control Unit)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EPS(Electronic power steering)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TBM(Tracking and Blocking Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TCM(Transmission Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PATS(Passive Anti Theft System)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PCM(PowerTrain Control Module)					V												V																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	ABS(Anti-Lock Brake System)																		V	V																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CMR(Camera Module Rear)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	D_DCU(Driver Door Control Unit)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EPS(Electronic Power Steering)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FACM(Fuel Additive Control Module)								V	V																																										
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	GEM(Generic Electronic Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FUSION GASOLINE1.4L	SYSTEM SEARCH																																																		
BETA-TEST	FUSION GASOLINE1.4L	PCM(Powertrain Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FUSION GASOLINE1.4L	ACM(Audio Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	APIM(Accessory Protocol Interface Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	BCMii(Body Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	DDM(Driver's Door Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	FDSM(Front Distance Sensing Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	FCDIM(Front Control/Display Interface Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	GPSM(Global Positioning System Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	GWM(Gateway Module A)																																																		
BETA-TEST	FUSION GASOLINE1.4L	HVAC(Heating Ventilation Air Conditioning)																																																		
BETA-TEST	FUSION GASOLINE1.4L	IPC(Instrument Panel Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	PDM(Passenger's Door Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	PSCM(Power Steering Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	RCM(Restraint Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	RFA(Remote Function Actuator)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	TCM(Transmission Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IC(Instrument Cluster)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	GEM(Generic Electronic Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ACM(Audio Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	BCMii(Body Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	FCDIM(Front Control/Display Interface Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IPC(Instrument Panel Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PSCM(Power Steering Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RCM(Retraint Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RFA(Remote Function Actuator)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SRM(Speech Recognition Module)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SYSTEM SEARCH																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	TCM(Transmission Control Module)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	IC(Instrument Cluster)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ACM(Audio Control Module)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)																																																		
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																																																		
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	TCM(Transmission Control Module)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	IC(Instrument Cluster)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	ACM(Audio Control Module)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	GEM(Generic Electronic Module)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	SRM(Speech Recognition Module)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	PATS(Passive Anti Theft System)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ACM(Audio Control Module)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	GEM(Generic Electronic Module)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	IC(Instrument Cluster)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SRM(Speech Recognition Module)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PATS(Passive Anti Theft System)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	SYSTEM SEARCH																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PCM(PowerTrain Control Module)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	IC(Instrument Cluster)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RCM(Restraint Control Module)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RKE(Remote Keyless Entry)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	TCM(Transmission Control Module)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PATS(Passive Anti Theft System)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	SYSTEM SEARCH																																																		
BETA-TEST	MONDEO-2.0L DIESEL	PCM(PowerTrain Control Module)			V	V																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
BETA-TEST	MONDEO-2.0L DIESEL	ABS(Anti-Lock Brake System)																											V																						
BETA-TEST	MONDEO-2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
BETA-TEST	MONDEO-2.0L DIESEL	BCMii(Body Control Module)																												V	V	V	V																		
BETA-TEST	MONDEO-2.0L DIESEL	CCMii(Cruise Control Module)																																																
BETA-TEST	MONDEO-2.0L DIESEL	CMR(Camera Module Rear)																																																
BETA-TEST	MONDEO-2.0L DIESEL	DDM(Driver's Door Module)																																																
BETA-TEST	MONDEO-2.0L DIESEL	DSM(Driver's Seat Module)																																V																	
BETA-TEST	MONDEO-2.0L DIESEL	HCM(Headlamp Control Module)																																																	
BETA-TEST	MONDEO-2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
BETA-TEST	MONDEO-2.0L DIESEL	IPC(Instrument Panel Control Module)																																																	
BETA-TEST	MONDEO-2.0L DIESEL	PAM(Parking Aid Module)																																																	
BETA-TEST	MONDEO-2.0L DIESEL	PBM(Parking Brake Control Module)																																	V	V	V	V	V	V											
BETA-TEST	MONDEO-2.0L DIESEL	PDM(Passenger's Door Module)																																																	
BETA-TEST	MONDEO-2.0L DIESEL	PSCM(Power Steering Control Module)																																																	
BETA-TEST	MONDEO-2.0L DIESEL	RCM(Restraint Control Module)																																																	
BETA-TEST	MONDEO-2.0L DIESEL	RFA(Remote Function Actuator)																																																	
BETA-TEST	MONDEO-2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																	
BETA-TEST	MONDEO-2.0L DIESEL	SRM(Speech Recognition Module)																																																	
BETA-TEST	MONDEO-2.0L DIESEL	TCM(Transmission Control Module)																																									V	V	V	V	V				
BETA-TEST	MONDEO-2.0L DIESEL	TRM(Trailer Module)																																																	
BETA-TEST	MONDEO-2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	SYSTEM SEARCH																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	BCMii(Body Control Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	CMR(Camera Module Rear)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	DDM(Driver's Door Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	PAM(Parking Aid Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	RCM(Restraint Control Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	TCM(Transmission Control Module)																																									V	V	V	V	V				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	Fuel injector correction factors	Reset the Fuel Injector Learned Values	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Reset the High Pressure Fuel System Learned Values	Reset the Fuel Injector Learned Values-Cylinder1	Reset the Fuel Injector Learned Values-Cylinder2	Reset the Fuel Injector Learned Values-Cylinder3	Reset the Fuel Injector Learned Values-Cylinder4	Powertrain Control Module Central Car Configuration Update	Misfire Monitor Neutral Profile Correction	Reset the DPF learned values	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Beltminder Enable/Disable	Reset the Turbocharger Variable Vane Position Sensor Learned Values	Clear Self learning Data	Shift fork system learn	Pressure Sensor Calibration	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point	Module Configuration	DPF regeneration	Initialize the Exhaust Gas Related Component	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	LIN New Module Initialization-Test	RVC Configuration-Test	Passenger System Reset	Passenger Zero Seat Weight Test
BETA-TEST	MONDEO-2.5L GASOLINE	TRM(Trailer Module)																																																	
BETA-TEST	MONDEO-2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	SYSTEM SEARCH																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	PCM(PowerTrain Control Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	ACM(Audio Control Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	CDP(Compact Disc Player)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	GDM(Generic Display Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	GEM(Generic Electronic Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	NAV(Navigation System)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	RCM(Restraint Control Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	RETM(Rear Entertainment Module)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																																																	
BETA-TEST	MONDEO-3.0L Duratec-ST	SRM(Speech Recognition Module)																																																	
BETA-TEST	F-150 5.4L	SYSTEM SEARCH																																																	
BETA-TEST	F-150 5.4L	PCM(PowerTrain Control Module)																																																	
BETA-TEST	F-150 5.4L	4X4(4x4 Control Module)																																																	
BETA-TEST	F-150 5.4L	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	F-150 5.4L	DSM(Driver Seat Module)																																																	
BETA-TEST	F-150 5.4L	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	F-150 5.4L	IC(Instrument Cluster)																																																	
BETA-TEST	F-150 5.4L	PAM(Parking Aid Module)																																																	
BETA-TEST	F-150 5.4L	RCM(Restraint Control Module)																																																V	
BETA-TEST	F-150 5.4L	VSM(Vehicle Security Module)																																																	
BETA-TEST	F-150 5.4L	PATS(Passive Anti Theft System)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	SYSTEM SEARCH																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PCM(PowerTrain Control Module)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	IC(Instrument Cluster)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PAM(Parking Aid Module)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	RCM(Restraint Control Module)																																																	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	VSM(Vehicle Security Module)																																																	
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																	
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																	
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
Incode Calculator	~2010.05	All model																																																			
ESCAPE	Up to 2004	SYSTEM SEARCH																																																			
ESCAPE	Up to 2004	PCM(PowerTrain Control Module)																																																			
ESCAPE	Up to 2004	Immobilizer																																																			
ESCAPE	Up to 2004	ABS(Anti-Lock Brake System)																																																			
ESCAPE	Up to 2004	RCM(Restraint Control Module)																																																			
ESCAPE	Up to 2004	GEM(Generic Electronic Module)																																																			
ESCAPE	From 2004	SYSTEM SEARCH																																																			
ESCAPE	From 2004	PCM(PowerTrain Control Module)																																																			
ESCAPE	From 2004	PATS(Passive anti theft system)																																																			
ESCAPE	From 2004	ABS(Anti-Lock Brake System)																																																			
ESCAPE	From 2004	ABS(Anti-Lock Brake System)																																																			
ESCAPE	From 2004	RCM(Restraint Control Module)																																																			
ESCAPE	From 2004	IC(Instrument Cluster)																																																			
ESCAPE	From 2004	GEM(Generic Electronic Module)																																																			
EXPLORER	2011 MY	3.5L TiCVT	SYSTEM SEARCH																																																		
EXPLORER	2011 MY	3.5L TiCVT	PCM(Powertrain Control Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	ABS(Anti-Lock Brake System)																																																		
EXPLORER	2011 MY	3.5L TiCVT	ACM(Audio Control Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	APIM(Accessory Protocol Interface Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	BCM(Body Control Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	ATCM(All Terrain Control Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	C-CM(Cruise Control Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	CLM(Column Lock Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	DCSM(Driver-Dual Climate Contol Seat Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	DSM(Driver Seat Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	DSP(Digital Signal Processing Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	FCIM(Front Controls Interface Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	FCDIM(Front Control/Display Interface Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	FLM(Front Lighting Control Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	GPSM(Global Positioning System Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	HUD(Head Up Display)																																																		
EXPLORER	2011 MY	3.5L TiCVT	HVAC(Heating Ventilation Air Conditioning)																																																		
EXPLORER	2011 MY	3.5L TiCVT	IPC(Instrument Panel Control Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	LTM(Liftgate/Trunk Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	OCSM(Occupant Classification System Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	PAM(Parking Aid Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	PSCM(Power Steering Control Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	RCM(Restraint Control Module)																																																		
EXPLORER	2011 MY	3.5L TiCVT	RFA(Remote Function Actuator)																																																		
EXPLORER	2011 MY	3.5L TiCVT	RLCM-A(Rear Lighting Control Module A)																																																		
EXPLORER	2011 MY	3.5L TiCVT	SCCM(Streering Colume Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
EXPLORER	2011 MY	3.5L TiCVT	SOD-L(Side Obstacle Detection Control Module Left)																																																		
EXPLORER	2011 MY	3.5L TiCVT	SOD-R(Side Obstacle Detection Control Module Right)																																																		
EXPLORER	2011 MY	3.5L TiCVT	TPM(Tire Pressure Monitor)																																																		
EXPLORER	2010 MY	4.6L	SYSTEM SEARCH																																																		
EXPLORER	2010 MY	4.6L	PCM(Powertrain Control Module)																																																		
EXPLORER	2010 MY	4.6L	TCM(Transmission Control Module)																																																		
EXPLORER	2010 MY	4.6L	4X4(4x4 Control Module)																																																		
EXPLORER	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																		
EXPLORER	2010 MY	4.6L	ACM(Audio Control Module)																																																		
EXPLORER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																		
EXPLORER	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																		
EXPLORER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																		
EXPLORER	2010 MY	4.6L	DSM(Driver's Seat Module)																																																		
EXPLORER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
EXPLORER	2010 MY	4.6L	IC(Instrument Cluster)																																																		
EXPLORER	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																		
EXPLORER	2010 MY	4.6L	PAM(Parking Aid Module)																																																		
EXPLORER	2010 MY	4.6L	PRB(Power Running Board)																																																		
EXPLORER	2010 MY	4.6L	RCM(Restraint Control Module)																																																		
EXPLORER	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																		
EXPLORER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																		
EXPLORER	2009 MY	4.6L	SYSTEM SEARCH																																																		
EXPLORER	2009 MY	4.6L	PCM(Powertrain Control Module)																																																		
EXPLORER	2009 MY	4.6L	TCM(Transmission Control Module)																																																		
EXPLORER	2009 MY	4.6L	4X4(4x4 Control Module)																																																		
EXPLORER	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																		
EXPLORER	2009 MY	4.6L	ACM(Audio Control Module)																																																		
EXPLORER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																		
EXPLORER	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																		
EXPLORER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																		
EXPLORER	2009 MY	4.6L	DSM(Driver's Seat Module)																																																		
EXPLORER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
EXPLORER	2009 MY	4.6L	IC(Instrument Cluster)																																																		
EXPLORER	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																		
EXPLORER	2009 MY	4.6L	PAM(Parking Aid Module)																																																		
EXPLORER	2009 MY	4.6L	PRB(Power Running Board)																																																		
EXPLORER	2009 MY	4.6L	RCM(Restraint Control Module)																																																		
EXPLORER	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																		
EXPLORER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																		
EXPLORER	2008 MY	4.6L	SYSTEM SEARCH																																																		
EXPLORER	2008 MY	4.6L	PCM(Powertrain Control Module)																																																		
EXPLORER	2008 MY	4.6L	TCM(Transmission Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
EXPLORER	2008 MY	4.6L	4X4(4x4 Control Module)																																																		
EXPLORER	2008 MY	4.6L	ABS(Anti-Lock Brake System)																																																		
EXPLORER	2008 MY	4.6L	ACM(Audio Control Module)																																																		
EXPLORER	2008 MY	4.6L	DSM(Driver's Seat Module)																																																		
EXPLORER	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																		
EXPLORER	2008 MY	4.6L	GEM(Generic Electronic Module)																																																		
EXPLORER	2008 MY	4.6L	IC(Instrument Cluster)																																																		
EXPLORER	2008 MY	4.6L	OCSM(Occupant Classification System Module)																																																		
EXPLORER	2008 MY	4.6L	PAM(Parking Aid Module)																																																		
EXPLORER	2008 MY	4.6L	PRB(Power Running Board)																																																		
EXPLORER	2008 MY	4.6L	RCM(Restraint Control Module)																																																		
EXPLORER	2008 MY	4.6L	RETM(Rear Entertainment Module)																																																		
EXPLORER	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																		
EXPLORER	2007 MY	4.6L	SYSTEM SEARCH																																																		
EXPLORER	2007 MY	4.6L	PCM(Powertrain Control Module)																																																		
EXPLORER	2007 MY	4.6L	TCM(Transmission Control Module)																																																		
EXPLORER	2007 MY	4.6L	4X4(4x4 Control Module)																																																		
EXPLORER	2007 MY	4.6L	ABS(Anti-Lock Brake System)																																																		
EXPLORER	2007 MY	4.6L	ACM(Audio Control Module)																																																		
EXPLORER	2007 MY	4.6L	DSM(Driver's Seat Module)																																																		
EXPLORER	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																		
EXPLORER	2007 MY	4.6L	GEM(Generic Electronic Module)																																																		
EXPLORER	2007 MY	4.6L	IC(Instrument Cluster)																																																		
EXPLORER	2007 MY	4.6L	OCSM(Occupant Classification System Module)																																																		
EXPLORER	2007 MY	4.6L	PAM(Parking Aid Module)																																																		
EXPLORER	2007 MY	4.6L	PRB(Power Running Board)																																																		
EXPLORER	2007 MY	4.6L	RCM(Restraint Control Module)																																																		
EXPLORER	2007 MY	4.6L	RETM(Rear Entertainment Module)																																																		
EXPLORER	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																		
EXPLORER	2006 MY	4.6L	SYSTEM SEARCH																																																		
EXPLORER	2006 MY	4.6L	PCM(Powertrain Control Module)																																																		
EXPLORER	2006 MY	4.6L	TCM(Transmission Control Module)																																																		
EXPLORER	2006 MY	4.6L	4X4(4x4 Control Module)																																																		
EXPLORER	2006 MY	4.6L	ABS(Anti-Lock Brake System)																																																		
EXPLORER	2006 MY	4.6L	ACM(Audio Control Module)																																																		
EXPLORER	2006 MY	4.6L	DSM(Driver's Seat Module)																																																		
EXPLORER	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																		
EXPLORER	2006 MY	4.6L	GEM(Generic Electronic Module)																																																		
EXPLORER	2006 MY	4.6L	IC(Instrument Cluster)																																																		
EXPLORER	2006 MY	4.6L	OCSM(Occupant Classification System Module)																																																		
EXPLORER	2006 MY	4.6L	PAM(Parking Aid Module)																																																		
EXPLORER	2006 MY	4.6L	PRB(Power Running Board)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
EXPLORER	2006 MY	4.6L	RCM(Restraint Control Module)																																																		
EXPLORER	2006 MY	4.6L	RETM(Rear Entertainment Module)																																																		
EXPLORER	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																		
EXPLORER	2000 MY	SYSTEM SEARCH																																																			
EXPLORER	2000 MY	PCM(PowerTrain Control Module)																																																			
EXPLORER	2000 MY	ABS(Anti-Lock Brake System)																																																			
EXPLORER	2000 MY	RCM(Restraint Control Module)																																																			
EXPLORER	2000 MY	RIM(Remote Immobilizer Module)																																																			
EXPLORER	2000 MY	GEM(Generic Electronic Module)																																																			
EXPLORER	2000 MY	PAM(Parking Aid Module)																																																			
EXPLORER	1999 MY	SYSTEM SEARCH																																																			
EXPLORER	1999 MY	PCM(PowerTrain Control Module)																																																			
EXPLORER	1999 MY	ABS(Anti-Lock Brake System)																																																			
EXPLORER	1999 MY	RCM(Restraint Control Module)																																																			
EXPLORER	1999 MY	RIM(Remote Immobilizer Module)																																																			
EXPLORER	1999 MY	PAM(Parking Aid Module)																																																			
EXPLORER	1998 MY	SYSTEM SEARCH																																																			
EXPLORER	1998 MY	PCM(PowerTrain Control Module)																																																			
EXPLORER	1998 MY	ABS(Anti-Lock Brake System)																																																			
EXPLORER	1998 MY	RCM(Restraint Control Module)																																																			
EXPLORER	1998 MY	RIM(Remote Immobilizer Module)																																																			
EXPLORER	1997 MY	SYSTEM SEARCH																																																			
EXPLORER	1997 MY	PCM(PowerTrain Control Module)																																																			
EXPLORER	1997 MY	ABS(Anti-Lock Brake System)																																																			
EXPLORER	1997 MY	RCM(Restraint Control Module)																																																			
EXPLORER	1997 MY	RIM(Remote Immobilizer Module)																																																			
EXPLORER SPORT-TRAC	2010 MY	4.6L	SYSTEM SEARCH																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	PCM(Powertrain Control Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	TCM(Transmission Control Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	4X4(4x4 Control Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	ACM(Audio Control Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	DSM(Driver's Seat Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	IC(Instrument Cluster)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	PAM(Parking Aid Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	PRB(Power Running Board)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	RCM(Restraint Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
EXPLORER SPORT-TRAC	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	SYSTEM SEARCH																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	PCM(Powertrain Control Module)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	TCM(Transmission Control Module)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	4X4(4x4 Control Module)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	ACM(Audio Control Module)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	DSM(Driver's Seat Module)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	IC(Instrument Cluster)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	PAM(Parking Aid Module)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	PRB(Power Running Board)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	RCM(Restraint Control Module)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																		
EXPLORER SPORT-TRAC	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	SYSTEM SEARCH																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	PCM(Powertrain Control Module)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	TCM(Transmission Control Module)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	4X4(4x4 Control Module)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	ABS(Anti-Lock Brake System)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	ACM(Audio Control Module)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	DSM(Driver's Seat Module)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	GEM(Generic Electronic Module)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	IC(Instrument Cluster)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	OCSM(Occupant Classification System Module)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	PAM(Parking Aid Module)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	PRB(Power Running Board)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	RCM(Restraint Control Module)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	RETM(Rear Entertainment Module)																																																		
EXPLORER SPORT-TRAC	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	SYSTEM SEARCH																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	PCM(Powertrain Control Module)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	TCM(Transmission Control Module)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	4X4(4x4 Control Module)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	ABS(Anti-Lock Brake System)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
EXPLORER SPORT-TRAC	2007 MY	4.6L	DSM(Driver's Seat Module)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	GEM(Generic Electronic Module)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	IC(Instrument Cluster)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	OCSM(Occupant Classification System Module)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	PAM(Parking Aid Module)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	PRB(Power Running Board)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	RCM(Restraint Control Module)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	RETM(Rear Entertainment Module)																																																		
EXPLORER SPORT-TRAC	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	SYSTEM SEARCH																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	PCM(Powertrain Control Module)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	TCM(Transmission Control Module)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	4X4(4x4 Control Module)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	ABS(Anti-Lock Brake System)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	ACM(Audio Control Module)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	DSM(Driver's Seat Module)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	GEM(Generic Electronic Module)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	IC(Instrument Cluster)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	OCSM(Occupant Classification System Module)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	PAM(Parking Aid Module)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	PRB(Power Running Board)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	RCM(Restraint Control Module)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	RETM(Rear Entertainment Module)																																																		
EXPLORER SPORT-TRAC	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																		
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																		
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																		
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																		
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																		
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	BCM(Body Control Module)																																																		
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																		
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	GPSM(Global Positioning System Module)																																																		
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																		
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																		
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																		
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																		
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																		
ECOSPORT	1.5L	DURATEC VCT	SYSTEM SEARCH																																																		
ECOSPORT	1.5L	DURATEC VCT	PCM(Powertrain Control Module)																																																		
ECOSPORT	1.5L	DURATEC VCT	ABS(Anti-Lock Brake System)																																																		
ECOSPORT	1.5L	DURATEC VCT	ACM(Audio Control Module)																																																		
ECOSPORT	1.5L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																																																		
ECOSPORT	1.5L	DURATEC VCT	BCMii(Body Control Module)																																																		
ECOSPORT	1.5L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																																																		
ECOSPORT	1.5L	DURATEC VCT	GPSM(Global Positioning System Module)																																																		
ECOSPORT	1.5L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																		
ECOSPORT	1.5L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																		
ECOSPORT	1.5L	DURATEC VCT	PSCM(Power Steering Control Module)																																																		
ECOSPORT	1.5L	DURATEC VCT	RCM(Restraint Control Module)																																																		
ECOSPORT	1.5L	DURATEC VCT	RFA(Remote Function Actuator)																																																		
ECOSPORT	1.5L	DURATEC VCT	TCM(Transmission Control Module)																																																		
FIESTA	1.25L	DURATEC 16V	SYSTEM SEARCH																																																		
FIESTA	1.25L	DURATEC 16V	PCM(PowerTrain Control Module)																																																		
FIESTA	1.25L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.25L	DURATEC 16V	ACM(Audio Control Module)																																																		
FIESTA	1.25L	DURATEC 16V	APIM(Accessory Protocol Interface Module)																																																		
FIESTA	1.25L	DURATEC 16V	BCMii(Body Control Module)																																																		
FIESTA	1.25L	DURATEC 16V	DDM(Driver's Door Module)																																																		
FIESTA	1.25L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.25L	DURATEC 16V	FDSM(Front Distance Sensing Module)																																																		
FIESTA	1.25L	DURATEC 16V	GPSM(Global Positioning System Module)																																																		
FIESTA	1.25L	DURATEC 16V	HVAC(Heating Ventilation Air Conditioning)																																																		
FIESTA	1.25L	DURATEC 16V	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.25L	DURATEC 16V	PDM(Passenger's Door Module)																																																		
FIESTA	1.25L	DURATEC 16V	PSCM(Power Steering Control Module)																																																		
FIESTA	1.25L	DURATEC 16V	RCM(Restraint Control Module)																																																		
FIESTA	1.25L	DURATEC 16V	RFA(Remote Function Actuator)																																																		
FIESTA	1.4L GASOLINE	SYSTEM SEARCH																																																		
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																			
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)																																																			
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)																																																			
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																			
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																			
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																			
FIESTA	1.4L GASOLINE	APIM(Accessory Protocol Interface Module)																																																			
FIESTA	1.4L GASOLINE	PSCM(Power Steering Control Module)																																																			
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)																																																			
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)																																																			
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)																																																			
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)																																																			
FIESTA	1.4L GASOLINE	GEM(Generic Electronic Module)																																																			
FIESTA	1.4L GASOLINE	BCMii(Body Control Module)																																																			
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																			
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																			
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																			
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																			
FIESTA	1.4L GASOLINE	RFA(Remote Function Actuator)																																																			
FIESTA	1.4L GASOLINE	SRM(Speech Recognition Module)																																																			
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)																																																			
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)																																																			
FIESTA	1.4L GASOLINE	DDM(Driver's Door Module)																																																			
FIESTA	1.4L GASOLINE	FDSM(Front Distance Sensing Module)																																																			
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																			
FIESTA	1.4L GASOLINE	GPSM(Global Positioning System Module)																																																			
FIESTA	1.4L GASOLINE	PDM(Passenger's Door Module)																																																			
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																		
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																		
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)																																																		
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																		
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																		
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																		
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)																																																		
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																		
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																		
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																		
FIESTA	1.5L	TiVCT	SYSTEM SEARCH																																																		
FIESTA	1.5L	TiVCT	PCM(PowerTrain Control Module)																																																		
FIESTA	1.5L	TiVCT	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.5L	TiVCT	ACM(Audio Control Module)																																																		
FIESTA	1.5L	TiVCT	BCMii(Body Control Module)																																																		
FIESTA	1.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.5L	TiVCT	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.5L	TiVCT	PSCM(Power Steering Control Module)																																																		
FIESTA	1.5L	TiVCT	RCM(Retraint Control Module)																																																		
FIESTA	1.5L	TiVCT	RFA(Remote Function Actuator)																																																		
FIESTA	1.5L	TiVCT	SRM(Speech Recognition Module)																																																		
FIESTA	1.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																																																		
FIESTA	1.5L	TiVCT	TCM(Transmission Control Module)																																																		
FIESTA	1.6L GASOLINE	SYSTEM SEARCH																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																			
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																			
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																			
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)																																																			
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)																																																			
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																			
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																			
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																			
FIESTA	1.6L GASOLINE	PSCM(Power Steering Control Module)																																																			
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)																																																			
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)																																																			
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																			
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																			
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																			
FIESTA	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																			
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)																																																			
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)																																																			
FIESTA	1.6L GASOLINE	BCMii(Body Control Module)																																																			
FIESTA	1.6L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																			
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)																																																			
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)																																																			
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)																																																			
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)																																																			
FIESTA	1.6L ZETEC ROCAM	SYSTEM SEARCH																																																			
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)																																																			
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)																																																			
FIESTA	1.6L ZETEC ROCAM	ABS(Anti-Lock Brake System)																																																			
FIESTA	1.6L ZETEC ROCAM	IC(Instrument Cluster)																																																			
FIESTA	1.6L ZETEC ROCAM	RCM(Restraint Control Module)																																																			
FIESTA	1.6L ZETEC ROCAM	RKE(Remote Keyless Entry)																																																			
FIESTA	1.6L ZETEC ROCAM	TCM(Transmission Control Module)																																																			
FIESTA	1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																																			
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																			
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																			
FIESTA	1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																																																			
FIESTA	1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																																																			
FIESTA	1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																																																			
FIESTA	2.0L GASOLINE	SYSTEM SEARCH																																																			
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																			
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																			
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																			
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																			
FIESTA	2.0L GASOLINE	ACM(Audio Control Module)																																																			
FIESTA	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																			
FIESTA	2.0L GASOLINE	GEM(Generic Electronic Module)																																																			
FIESTA	2.0L GASOLINE	IC(Instrument Cluster)																																																			
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)																																																			
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)																																																			
FIESTA	2.0L GASOLINE	RCM(Restraint Control Module)																																																			
FIESTA	2.0L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																			
FIGO	1.4L DIESEL	SYSTEM SEARCH																																																			
FIGO	1.4L DIESEL	PCM(Powertrain Control Module)																																																			
FIGO	1.4L DIESEL	ABS(Anti-Lock Brake System)																																																			
FIGO	1.4L DIESEL	IC(Instrument Cluster)																																																			
FIGO	1.4L DIESEL	RCM(Restraint Control Module)																																																			
FIGO	1.6L	DURATEC 16V	SYSTEM SEARCH																																																		
FIGO	1.6L	DURATEC 16V	PCM(Powertrain Control Module)																																																		
FIGO	1.6L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																		
FIGO	1.6L	DURATEC 16V	GEM(Generic Electronic Module)																																																		
FIGO	1.6L	DURATEC 16V	IC(Instrument Cluster)																																																		
FIGO	1.6L	DURATEC 16V	RCM(Restraint Control Module)																																																		
FIGO	1.6L	DURATEC 16V	TCM(Transmission Control Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM(Front Distance Sensing Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																		
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																		
FOCUS	1.4L	DURATEC 16V	SYSTEM SEARCH																																																		
FOCUS	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																																																		
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.4L	DURATEC 16V	ACM(Audio Control Module)																																																		
FOCUS	1.4L	DURATEC 16V	CDP(Compact Disc Player)																																																		
FOCUS	1.4L	DURATEC 16V	D_DCU(Driver Door Control Unit)																																																		
FOCUS	1.4L	DURATEC 16V	GDM(Generic Display Module)																																																		
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																																																		
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																																																		
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)																																																		
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)																																																		
FOCUS	1.4L	DURATEC 16V	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS	1.4L	DURATEC 16V	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS	1.4L	DURATEC 16V	IC(Instrument Cluster)																																																		
FOCUS	1.4L	DURATEC 16V	NAV(Navigation System)																																																		
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)																																																		
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)																																																		
FOCUS	1.4L	DURATEC 16V	PDM(Passenger's Door Module)																																																		
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)																																																		
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)																																																		
FOCUS	1.4L	DURATEC 16V	RKE(Remote Keyless Entry)																																																		
FOCUS	1.4L	DURATEC 16V	CSM(Central Security Module)																																																		
FOCUS	1.4L	DURATEC 16V	HEC(Hybrid Electrical Cluster)																																																		
FOCUS	1.4L	DURATEC 16V	MC(Message Center)																																																		
FOCUS	1.4L	DURATEC 16V	RETM(Rear Entertainment Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TCM(Transmission Control Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body control module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	CCMii(Cruise Control Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	DDM(Driver's Door Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	DDM(Driver's Door Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FCIM(Front Controls Interface Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FDSM(Front Distance Sensing Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FCDIM(Front Control/Display Interface Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	GPSM(Global Positioning System Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	HCM(Headlamp Control Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	HVAC(Heating Ventilation Air Conditioning)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	IPM-A(Image Processing Module A)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	IPC(Instrument Panel Control Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PAM(Parking Aid Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PDM(Passenger's Door Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PSCM(Power Steering Control Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	RCM(Restraint Control Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	RFA(Remote Function Actuator)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SASM(Steering Angle Sensor Module)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SOD-L(Side Obstacle Detection Control Module Left)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SOD-R(Side Obstacle Detection Control Module Right)																																																		
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	TRM(Trailer Module)																																																		
FOCUS	1.6L GASOLINE	ZETEC SE	SYSTEM SEARCH																																																		
FOCUS	1.6L GASOLINE	ZETEC SE	PCM(PowerTrain Control Module)																																																		
FOCUS	1.6L GASOLINE	ZETEC SE	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.6L GASOLINE	ZETEC SE	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS	1.6L GASOLINE	ZETEC SE	GEM(Generic Electronic Module)																																																		
FOCUS	1.6L GASOLINE	ZETEC SE	RCM(Restraint Control Module)																																																		
FOCUS	1.6L GASOLINE	ZETEC SE	MC(Message Center)																																																		
FOCUS	1.6L GASOLINE	DURATEC	SYSTEM SEARCH																																																		
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.6L GASOLINE	DURATEC	ACM(Audio Control Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	CDP(Compact Disc Player)																																																		
FOCUS	1.6L GASOLINE	DURATEC	D_DCU(Driver Door Control Unit)																																																		
FOCUS	1.6L GASOLINE	DURATEC	GDM(Generic Display Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS	1.6L GASOLINE	DURATEC	FFH(Fuel Fired Coolant Heating Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FOCUS	1.6L GASOLINE	DURATEC	IC(Instrument Cluster)																																																		
FOCUS	1.6L GASOLINE	DURATEC	NAV(Navigation System)																																																		
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	PDM(Passenger's Door Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	RKE(Remote Keyless Entry)																																																		
FOCUS	1.6L GASOLINE	DURATEC	RL_DCU(Rear Left Door Control Unit)																																																		
FOCUS	1.6L GASOLINE	DURATEC	RR_DCU(Rear Right Door Control Unit)																																																		
FOCUS	1.6L GASOLINE	DURATEC	CSM(Central Security Module)																																																		
FOCUS	1.6L GASOLINE	DURATEC	HEC(Hybrid Electrical Cluster)																																																		
FOCUS	1.6L GASOLINE	DURATEC	MC(Message Center)																																																		
FOCUS	1.6L GASOLINE	DURATEC	PATS(Passive Anti Theft System)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SYSTEM SEARCH																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TCM(Transmission Control Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	APIM(Accessory Protocol Interface Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	BCMii(Body Control Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	CCMii(Cruise Control Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DDM(Driver's Door Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DSP(Digital Signal Processing Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCIM(Front Controls Interface Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FDSM(Front Distance Sensing Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCDIM(Front Control/Display Interface Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HCM(Headlamp Control Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-A(Image Processing Module A)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-B(Image Processing Module B)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPC(Instrument Panel Control Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PSCM(Power Steering Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RFA(Remote Function Actuator)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SASM(Steering Angle Sensor Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SRM(Speech Recognition Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TRM(Trailer Module)																																																		
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PATS(Passive Anti Theft System)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GDM(Generic Display Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	NAV(Navigation System)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Condtioning)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Condtioning)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)																																																		
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CMR(Camera Module Rear)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CDP(Compact Disc Player)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPB(Electronic Parking Brake)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPS(Electronic Power Steering)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GDM(Generic Display Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HCM(Headlamp Control Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	IC(Instrument Cluster)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	NAV(Navigation System)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PDM(Passenger's Door Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CSM(Central Security Module)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	MC(Message Center)																																																		
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SYSTEM SEARCH																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	TCM(Transmission Control Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ACM(Audio Control Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CMR(Camera Module Rear)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CDP(Compact Disc Player)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CSM(Central Security Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPB(Electronic Parking Brake)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPS(Electronic Power Steering)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GDM(Generic Display Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HCM(Headlamp Control Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	IC(Instrument Cluster)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	NAV(Navigation System)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PAM(Parking Aid Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PDM(Passenger's Door Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SRM(Speech Recognition Module)																																																		
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SYSTEM SEARCH																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TCM(Transmission Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	AHCM(Auxiliary Heater Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	APIM(Accessory Protocol Interface Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	BCMii(Body Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	CCMii(Cruise Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DDM(Driver's Door Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DSP(Digital Signal Processing Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCIM(Front Controls Interface Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FDSM(Front Distance Sensing Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCDIM(Front Control/Display Interface Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HCM(Headlamp Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-A(Image Processing Module A)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-B(Image Processing Module B)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPC(Instrument Panel Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PSCM(Power Steering Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RFA(Remote Function Actuator)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SASM(Steering Angle Sensor Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SRM(Speech Recognition Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TRM(Trailer Module)																																																		
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PATS(Passive Anti Theft System)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	SYSTEM SEARCH																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PCM(PowerTrain Control Module)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	TCM(Transmission Control Module)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ACM(Audio Control Module)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ABS(Anti-Lock Brake System)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CDP(Compact Disc Player)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CMR(Camera Module Rear)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	D_DCU(Driver Door Control Unit)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	EPS(Electronic Power Steering)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FACM(Fuel Additive Control Module)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	GEM(Generic Electronic Module)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	HCM(Headlamp Control Module)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	IC(Instrument Cluster)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PDM(Passenger's Door Module)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PAM(Parking Aid Module)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RCM(Restraint Control Module)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RETM(Rear Entertainment Module)																																																		
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RKE(Remote Keyless Entry)																																																		
FOCUS	2.5L GASOLINE	SYSTEM SEARCH																																																			
FOCUS	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																			
FOCUS	2.5L GASOLINE	TCM(Transmission Control Module)																																																			
FOCUS	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																			
FOCUS	2.5L GASOLINE	EPS(Electronic Power Steering)																																																			
FOCUS	2.5L GASOLINE	RCM(Restraint Control Module)																																																			
FOCUS	2.5L GASOLINE	GEM(Generic Electronic Module)																																																			
FOCUS	2.5L GASOLINE	IC(Instrument Cluster)																																																			
FOCUS	2.5L GASOLINE	DDM(Driver's Door Module)																																																			
FOCUS	2.5L GASOLINE	PDM(Passenger's Door Module)																																																			
FOCUS	2.5L GASOLINE	MC(Message Center)																																																			
FOCUS	2.5L GASOLINE	ACM(Audio Control Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FOCUS C-MAX	1.6L DIESEL	SYSTEM SEARCH																																																			
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																			
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																			
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	CDP(Compact Disc Player)																																																			
FOCUS C-MAX	1.6L DIESEL	CMR(Camera Module Rear)																																																			
FOCUS C-MAX	1.6L DIESEL	D_DCU(Driver Door Control Unit)																																																			
FOCUS C-MAX	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)																																																			
FOCUS C-MAX	1.6L DIESEL	EPS(Electronic Power Steering)																																																			
FOCUS C-MAX	1.6L DIESEL	FACM(Fuel Additive Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																			
FOCUS C-MAX	1.6L DIESEL	GEM(Generic Electronic Module)																																																			
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	IC(Instrument Cluster)																																																			
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)																																																			
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)																																																			
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)																																																			
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)																																																			
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	RETM(Rear Entertainment Module)																																																			
FOCUS C-MAX	1.6L DIESEL	RKE(Remote Keyless Entry)																																																			
FOCUS C-MAX	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	BCMii(Body Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	DDM(Driver's Door Module)																																																			
FOCUS C-MAX	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)																																																			
FOCUS C-MAX	1.6L DIESEL	HVAC(Heating Ventilation Air Condtioning)																																																			
FOCUS C-MAX	1.6L DIESEL	IPM-A(Image Processing Module A)																																																			
FOCUS C-MAX	1.6L DIESEL	IPM-B(Image Processing Module B)																																																			
FOCUS C-MAX	1.6L DIESEL	IPC(Instrument Panel Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	PSCM(Power Steering Control Module)																																																			
FOCUS C-MAX	1.6L DIESEL	RFA(Remote Function Actuator)																																																			
FOCUS C-MAX	1.6L DIESEL	RGTM(Rear Gate/Trunk Module)																																																			
FOCUS C-MAX	1.6L DIESEL	SASM(Steering Angle Sensor Module)																																																			
FOCUS C-MAX	1.6L DIESEL	SRM(Speech Recognition Module)																																																			
FOCUS C-MAX	1.6L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																			
FOCUS C-MAX	1.6L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																			
FOCUS C-MAX	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FOCUS C-MAX	1.6L GASOLINE	SYSTEM SEARCH																																																			
FOCUS C-MAX	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																			
FOCUS C-MAX	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																			
FOCUS C-MAX	1.6L GASOLINE	ACM(Audio Control Module)																																																			
FOCUS C-MAX	1.6L GASOLINE	CDP(Compact Disc Player)																																																			
FOCUS C-MAX	1.6L GASOLINE	CMR(Camera Module Rear)																																																			
FOCUS C-MAX	1.6L GASOLINE	D_DCU(Driver Door Control Unit)																																																			
FOCUS C-MAX	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																			
FOCUS C-MAX	1.6L GASOLINE	EPS(Electronic Power Steering)																																																			
FOCUS C-MAX	1.6L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																			
FOCUS C-MAX	1.6L GASOLINE	GEM(Generic Electronic Module)																																																			
FOCUS C-MAX	1.6L GASOLINE	HCM(Headlamp Control Module)																																																			
FOCUS C-MAX	1.6L GASOLINE	IC(Instrument Cluster)																																																			
FOCUS C-MAX	1.6L GASOLINE	PAM(Parking Aid Module)																																																			
FOCUS C-MAX	1.6L GASOLINE	PDM(Passenger's Door Module)																																																			
FOCUS C-MAX	1.6L GASOLINE	RCM(Restraint Control Module)																																																			
FOCUS C-MAX	1.6L GASOLINE	RETM(Rear Entertainment Module)																																																			
FOCUS C-MAX	1.6L GASOLINE	RKE(Remote Keyless Entry)																																																			
FOCUS C-MAX	1.6L GASOLINE	GDM(Generic Display Module)																																																			
FOCUS C-MAX	1.6L GASOLINE	NAV(Navigation System)																																																			
FOCUS C-MAX	1.6L GASOLINE	RL_DCU(Rear Left Door Control Unit)																																																			
FOCUS C-MAX	1.6L GASOLINE	RR_DCU(Rear Right Door Control Unit)																																																			
FOCUS C-MAX	1.6L GASOLINE	SRM(Speech Recognition Module)																																																			
FOCUS C-MAX	1.6L GASOLINE	TCM(Transmission Control Module)																																																			
FOCUS C-MAX	1.8L GASOLINE	SYSTEM SEARCH																																																			
FOCUS C-MAX	1.8L GASOLINE	PCM(PowerTrain Control Module)																																																			
FOCUS C-MAX	1.8L GASOLINE	ABS(Anti-Lock Brake System)																																																			
FOCUS C-MAX	1.8L GASOLINE	ACM(Audio Control Module)																																																			
FOCUS C-MAX	1.8L GASOLINE	CMR(Camera Module Rear)																																																			
FOCUS C-MAX	1.8L GASOLINE	CDP(Compact Disc Player)																																																			
FOCUS C-MAX	1.8L GASOLINE	D_DCU(Driver Door Control Unit)																																																			
FOCUS C-MAX	1.8L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																			
FOCUS C-MAX	1.8L GASOLINE	EPB(Electronic Parking Brake)																																																			
FOCUS C-MAX	1.8L GASOLINE	EPS(Electronic Power Steering)																																																			
FOCUS C-MAX	1.8L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																			
FOCUS C-MAX	1.8L GASOLINE	GDM(Generic Display Module)																																																			
FOCUS C-MAX	1.8L GASOLINE	GEM(Generic Electronic Module)																																																			
FOCUS C-MAX	1.8L GASOLINE	HCM(Headlamp Control Module)																																																			
FOCUS C-MAX	1.8L GASOLINE	IC(Instrument Cluster)																																																			
FOCUS C-MAX	1.8L GASOLINE	NAV(Navigation System)																																																			
FOCUS C-MAX	1.8L GASOLINE	PAM(Parking Aid Module)																																																			
FOCUS C-MAX	1.8L GASOLINE	PDM(Passenger's Door Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FOCUS C-MAX	1.8L GASOLINE	RCM(Restraint Control Module)																																																			
FOCUS C-MAX	1.8L GASOLINE	RETM(Rear Entertainment Module)																																																			
FOCUS C-MAX	1.8L GASOLINE	RKE(Remote Keyless Entry)																																																			
FOCUS C-MAX	1.8L GASOLINE	SRM(Speech Recognition Module)																																																			
FOCUS C-MAX	2.0L DIESEL	SYSTEM SEARCH																																																			
FOCUS C-MAX	2.0L DIESEL	PCM(PowerTrain Control Module)																																																			
FOCUS C-MAX	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																			
FOCUS C-MAX	2.0L DIESEL	ACM(Audio Control Module)																																																			
FOCUS C-MAX	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																			
FOCUS C-MAX	2.0L DIESEL	BCMii(Body Control Module)																																																			
FOCUS C-MAX	2.0L DIESEL	DDM(Driver's Door Module)																																																			
FOCUS C-MAX	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																																																			
FOCUS C-MAX	2.0L DIESEL	HCM(Headlamp Control Module)																																																			
FOCUS C-MAX	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																			
FOCUS C-MAX	2.0L DIESEL	IPM-A(Image Processing Module A)																																																			
FOCUS C-MAX	2.0L DIESEL	IPM-B(Image Processing Module B)																																																			
FOCUS C-MAX	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																			
FOCUS C-MAX	2.0L DIESEL	PAM(Parking Aid Module)																																																			
FOCUS C-MAX	2.0L DIESEL	PDM(Passenger's Door Module)																																																			
FOCUS C-MAX	2.0L DIESEL	PSCM(Power Steering Control Module)																																																			
FOCUS C-MAX	2.0L DIESEL	RCM(Restraint Control Module)																																																			
FOCUS C-MAX	2.0L DIESEL	RFA(Remote Function Actuator)																																																			
FOCUS C-MAX	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																			
FOCUS C-MAX	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																			
FOCUS C-MAX	2.0L DIESEL	SRM(Speech Recognition Module)																																																			
FOCUS C-MAX	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																			
FOCUS C-MAX	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																			
FOCUS C-MAX	2.0L GASOLINE	SYSTEM SEARCH																																																			
FOCUS C-MAX	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																			
FOCUS C-MAX	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																			
FOCUS C-MAX	2.0L GASOLINE	ACM(Audio Control Module)																																																			
FOCUS C-MAX	2.0L GASOLINE	CDP(Compact Disc Player)																																																			
FOCUS C-MAX	2.0L GASOLINE	CMR(Camera Module Rear)																																																			
FOCUS C-MAX	2.0L GASOLINE	D_DCU(Driver Door Control Unit)																																																			
FOCUS C-MAX	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																			
FOCUS C-MAX	2.0L GASOLINE	EPB(Electronic Parking Brake)																																																			
FOCUS C-MAX	2.0L GASOLINE	EPS(Electronic Power Steering)																																																			
FOCUS C-MAX	2.0L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																			
FOCUS C-MAX	2.0L GASOLINE	GDM(Generic Display Module)																																																			
FOCUS C-MAX	2.0L GASOLINE	GEM(Generic Electronic Module)																																																			
FOCUS C-MAX	2.0L GASOLINE	HCM(Headlamp Control Module)																																																			
FOCUS C-MAX	2.0L GASOLINE	IC(Instrument Cluster)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
FOCUS C-MAX	2.0L GASOLINE	NAV(Navigation System)																																																			
FOCUS C-MAX	2.0L GASOLINE	PAM(Parking Aid Module)																																																			
FOCUS C-MAX	2.0L GASOLINE	PDM(Passenger's Door Module)																																																			
FOCUS C-MAX	2.0L GASOLINE	RCM(Restraint Control Module)																																																			
FOCUS C-MAX	2.0L GASOLINE	RETM(Rear Entertainment Module)																																																			
FOCUS C-MAX	2.0L GASOLINE	RKE(Remote Keyless Entry)																																																			
FOCUS C-MAX	2.0L GASOLINE	SRM(Speech Recognition Module)																																																			
FUSION	1.4L DIESEL	SYSTEM SEARCH																																																			
FUSION	1.4L DIESEL	PCM(PowerTrain Control Module)																																																			
FUSION	1.4L DIESEL	TCM(Transmission Control Module)																																																			
FUSION	1.4L DIESEL	ABS(Anti-Lock Brake System)																																																			
FUSION	1.4L DIESEL	IC(Instrument Cluster)																																																			
FUSION	1.4L DIESEL	ACM(Audio Control Module)																																																			
FUSION	1.4L DIESEL	EATC(Electronic Automatic Temperature Control)																																																			
FUSION	1.4L DIESEL	GEM(Generic Electronic Module)																																																			
FUSION	1.4L DIESEL	SRM(Speech Recognition Module)																																																			
FUSION	1.4L DIESEL	RCM(Restraint Control Module)																																																			
FUSION	1.4L DIESEL	PATS(Passive Anti Theft System)-BETA																																																			
FUSION	1.6L DIESEL	SYSTEM SEARCH																																																			
FUSION	1.6L DIESEL	PCM(PowerTrain Control Module)																																																			
FUSION	1.6L DIESEL	TCM(Transmission Control Module)																																																			
FUSION	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																			
FUSION	1.6L DIESEL	IC(Instrument Cluster)																																																			
FUSION	1.6L DIESEL	ACM(Audio Control Module)																																																			
FUSION	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)																																																			
FUSION	1.6L DIESEL	GEM(Generic Electronic Module)																																																			
FUSION	1.6L DIESEL	SRM(Speech Recognition Module)																																																			
FUSION	1.6L DIESEL	RCM(Restraint Control Module)																																																			
FUSION	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																																			
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																		
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																		
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																		
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TCM(Transmission Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CDP(Compact Disc Player)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CMR(Camera Module Rear)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DABM(Digital Audio Broadcast Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver's Seat Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	NAV(Navigation System)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PBM(Parking Brake Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RHVAC(Rear Heating Ventilation Air Conditioning)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module - Left)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module - Right)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																		
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)		V																																																
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																																																		
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																																																		
F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																																																		
F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																																																		
F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																																																		
F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																																																		
F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																																																		
F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																																																		
F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																																																		
F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																																																		
F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																																																		
F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																																																		
F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)		V																																																
F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																																																		
F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																																																		
F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																																																		
F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																																																		
F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																																																		
F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																																																		
F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																																																		
F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																																																		
F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																																																		
F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																																																		
F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																																																		
F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																																																		
F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																																																	
F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)		V	V																																														
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)				V																																													
F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)					V																																												
F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																																																	
F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																																																	
F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)						V																																											
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)							V	V	V	V	V																																						
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																																																	
F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																																																	
F150	4.6L(BETA)	3V	SYSTEM SEARCH																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																																																		
F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																																																		
F150	4.6L(BETA)	3V	ACM(Audio Control Module)			V	V																																														
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																																																		
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																																																		
F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)					V																																													
F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																																																		
F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																																																		
F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																																																		
F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)						V																																												
F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																																																		
F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																																																		
F150	4.6L(BETA)	3V	IC(Instrument Cluster)																																																		
F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																																																		
F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																																																		
F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																																																		
F150	4.6L(BETA)	3V	PRB(Power Running Board)																																																		
F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																																																		
F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																																																		
F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																																																		
F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																																																		
F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																																																		
F150	5.0L	TiVCT	SYSTEM SEARCH																																																		
F150	5.0L	TiVCT	PCM(Powertrain Control Module)																																																		
F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																																																		
F150	5.0L	TiVCT	ACM(Audio Control Module)			V	V																																														
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																																																		
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																																																		
F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)					V																																													
F150	5.0L	TiVCT	DSM(Driver's Seat Module)																																																		
F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																																																		
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																		
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)													V																																					
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																		
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																		
F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																																																		
F150	5.0L	TiVCT	FDIM(Front Display Interface Module)						V																																												
F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																																																		
F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																																																		
F150	5.0L	TiVCT	IC(Instrument Cluster)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																																																		
F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																																																		
F150	5.0L	TiVCT	PAM(Parking Aid Module)																																																		
F150	5.0L	TiVCT	PAM(Parking Aid Module)																																																		
F150	5.0L	TiVCT	PRB(Power Running Board)																																																		
F150	5.0L	TiVCT	PSCM(Power Steering Control Module)		V																																																
F150	5.0L	TiVCT	RCM(Restraint Control Module)																																																		
F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																																																		
F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																																																		
F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																																																		
F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																																																		
F150	5.0L	TiVCT	TCM(Transmission Control Module)																																																		
F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																																																		
F150	5.4L	3V	2009 ~	SYSTEM SEARCH																																																	
F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																																																	
F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																																																	
F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																																																	
F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																																																	
F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)				V																																													
F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																																																	
F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																																																	
F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																																																	
F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)					V																																												
F150	5.4L	3V	2009 ~	GEMS3B(Generic Electronic Module/Smart Junction Box)																																																	
F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																																																	
F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																																																	
F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																																																	
F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																																																	
F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																																																	
F150	5.4L	3V	2009 ~	PRB(Power Running Board)																																																	
F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																																																	
F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																																																	
F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																																																	
F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																																																	
F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																																																	
F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																																																	
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)						V																																											
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																																																	
F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																																																	
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																	
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																																																	
F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																																																	
F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																																																	
F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																																																	
F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																																																	
F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																																																	
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																																																	
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																																																	
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)							V	V	V	V	V																																						
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																																																	
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																																																	
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																																																	
F150	6.2L(BETA)	2V	SYSTEM SEARCH																																																		
F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																																																		
F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																																																		
F150	6.2L(BETA)	2V	ACM(Audio Control Module)			V	V																																														
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																																																		
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																																																		
F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																																																		
F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																																																		
F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																																																		
F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)						V																																												
F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																																																		
F150	6.2L(BETA)	2V	IC(Instrument Cluster)																																																		
F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																																																		
F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																																																		
F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																																																		
F150	6.2L(BETA)	2V	PRB(Power Running Board)																																																		
F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																																																		
F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																																																		
F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																																																		
F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																																																		
F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																																																		
F150	Other	2004 ~ 2008	SYSTEM SEARCH																																																		
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)							V																																											
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																																																		
F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																																																		
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																		
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																		
F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																																																		
F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																																																		
F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																																		
F150	Other	2004 ~ 2008	IC(Instrument Cluster)																																																		
F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																																																		
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																																																		
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																																																		
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)								V	V	V	V	V																																						
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																																																		
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																																																		
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																																																		
F250	7.3L	SYSTEM SEARCH																																																			
F250	7.3L	PCM(PowerTrain Control Module)															V	V	V																																		
F250	7.3L	ABS(Anti-Lock Brake System)																																																			
F250	7.3L	ECS(Electronic Crash Sensor)																																																			
F250	7.3L	GEM(Generic Electronic Module)																																																			
F250	6.2L	SYSTEM SEARCH																																																			
F250	6.2L	PCM(Powertrain Control Module)																																																			
F250	6.2L	ABS(Anti-Lock Brake System)																		V																																	
F250	6.2L	ACM(Audio Control Module)			V	V																																															
F250	6.2L	APIM(Accessory Protocol Interface Module)																																																			
F250	6.2L	BCMii(Body Control Module)																																																			
F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																																																			
F250	6.2L	DSM(Driver Seat Module)																																																			
F250	6.2L	GPSM(Global Positioning System Module)																																																			
F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																																																			
F250	6.2L	IPC(Instrument Panel Control Module)																																																			
F250	6.2L	PAM(Parking Aid Module)																																																			
F250	6.2L	RCM(Restraint Control Module)																																																			
F250	6.2L	SCCM(Streering Colume Control Module)																																																			
F250	6.2L	TBC(Trailer Brake Control Module)																																																			
F250	6.2L	TCCM(Transfer Case Control Module)																																																			
F250	6.2L	TPM(Tire Pressure Monitor)																																																			
F250	6.0L Diesel	SYSTEM SEARCH																																																			
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																			
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																			
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																			
F250	6.0L Diesel	ABS(Anti-Lock Brake System)																																																			
F250	6.0L Diesel	GEM(Generic Electronic Module)																																																			
F250	6.0L Diesel	HEC(Hybrid Electrical Cluster)																																																			
F250	6.0L Diesel	OTC(Overhead Trip Computer)																																																			
F250	6.0L Diesel	PAM(Parking Aid Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
F250	6.0L Diesel	PATS(Passive Anti Theft System)																																																			
F250	6.0L Diesel	RCM(Restraint Control Module)																																																			
F250	6.0L Diesel	TCM(Transmission Control Module)																																																			
F250	6.0L Diesel	TCM(Transmission Control Module)																																																			
F250	6.0L Diesel	TCM(Transmission Control Module)																																																			
F250	6.0L Diesel	VSM(Vehicle Security Module)																																																			
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																																																		
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																	V	V	V	V	V	V	V	V	V	V																								
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																											V																						
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)				V																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																	V	V	V	V	V	V	V	V	V	V																								
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																V																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)				V																																												
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																																																
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																	
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																	
KA	KA	SYSTEM SEARCH																																																		
KA	KA	PCM(PowerTrain Control Module)																																																		
KA	KA	ABS(Anti-Lock Brake System)																																																		
KA	KA	RCM(Restraint Control Module)																																																		
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																												V	V	V																			
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																																V	V	V															
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)		V																																	V														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
KUGA	2.0L DIESEL	SYSTEM SEARCH																																																		
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)																																					V	V	V												
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)																																								V										
KUGA	2.0L DIESEL	TCM(Transmission Control Module)																																																		
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																		
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																		
KUGA	2.0L DIESEL	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
KUGA	2.0L DIESEL	ACM(Audio Control Module)																																																			
KUGA	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																			
KUGA	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																																																			
KUGA	2.0L DIESEL	AWD(All Wheel Drive Module)																																																			
KUGA	2.0L DIESEL	BCMii(Body Control Module)																																																			
KUGA	2.0L DIESEL	CCMii(Cruise Control Module)																																																			
KUGA	2.0L DIESEL	CMR(Camera Module Rear)																																																			
KUGA	2.0L DIESEL	D_DCU(Driver Door Control Unit)																																																			
KUGA	2.0L DIESEL	DDM(Driver's Door Module)																																																			
KUGA	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																			
KUGA	2.0L DIESEL	EPS(Electronic Power Steering)																																																			
KUGA	2.0L DIESEL	FDSM(Front Distance Sensing Module)																																																			
KUGA	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																																																			
KUGA	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																			
KUGA	2.0L DIESEL	GEM(Generic Electronic Module)																																																			
KUGA	2.0L DIESEL	GPSM(Global Positioning System Module)																																																			
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)																																																			
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)																																																			
KUGA	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																			
KUGA	2.0L DIESEL	IPM-A(Image Processing Module A)																																																			
KUGA	2.0L DIESEL	IPM-B(Image Processing Module B)																																																			
KUGA	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																			
KUGA	2.0L DIESEL	IC(Instrument Cluster)																																																			
KUGA	2.0L DIESEL	PAM(Parking Aid Module)																																																			
KUGA	2.0L DIESEL	PAM(Parking Aid Module)																																																			
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)																																																			
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)																																																			
KUGA	2.0L DIESEL	PSCM(Power Steering Control Module)																																																			
KUGA	2.0L DIESEL	RCM(Restraint Control Module)																																																			
KUGA	2.0L DIESEL	RCM(Restraint Control Module)																																																			
KUGA	2.0L DIESEL	RFA(Remote Function Actuator)																																																			
KUGA	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																			
KUGA	2.0L DIESEL	RETM(Rear Entertainment Module)																																																			
KUGA	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																			
KUGA	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																			
KUGA	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																			
KUGA	2.0L DIESEL	SRM(Speech Recognition Module)																																																			
KUGA	2.0L DIESEL	TRM(Trailer Module)																																																			
KUGA	2.5L GASOLINE	SYSTEM SEARCH																																																			
KUGA	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																			
KUGA	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																			
KUGA	2.5L GASOLINE	ACM(Audio Control Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
KUGA	2.5L GASOLINE	AWD(All Wheel Drive Module)																																																			
KUGA	2.5L GASOLINE	CMR(Camera Module Rear)																																																			
KUGA	2.5L GASOLINE	D_DCU(Driver Door Control Unit)																																																			
KUGA	2.5L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																			
KUGA	2.5L GASOLINE	EPS(Electronic Power Steering)																																																			
KUGA	2.5L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																			
KUGA	2.5L GASOLINE	GEM(Generic Electronic Module)																																																			
KUGA	2.5L GASOLINE	HCM(Headlamp Control Module)																																																			
KUGA	2.5L GASOLINE	IC(Instrument Cluster)																																																			
KUGA	2.5L GASOLINE	PAM(Parking Aid Module)																																																			
KUGA	2.5L GASOLINE	PDM(Passenger's Door Module)																																																			
KUGA	2.5L GASOLINE	RCM(Restraint Control Module)																																																			
KUGA	2.5L GASOLINE	RETM(Rear Entertainment Module)																																																			
KUGA	2.5L GASOLINE	RKE(Remote Keyless Entry)																																																			
KUGA	2.5L GASOLINE	SRM(Speech Recognition Module)																																																			
KUGA	2.5L GASOLINE	TCM(Transmission Control Module)																																																			
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																		
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SDD-R(Side Obstacle Detection Control Module - Right)																																																	
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)																																							V	V	V	V							
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)																																										V	V	V	V			
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body Control Module)																										V																					V	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	CCMii(Cruise Control Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DCDC(DC to DC Convertal Control Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DDM(Driver's Door Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSM(Driver Seat Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSP(Digital Signal Processing Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCIM(Front Controls Interface Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FDSM(Front Distance Sensing Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCDIM(Front Control/Display Interface Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GPSM(Global Positioning System Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GWM(Gateway Module A)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HCM(Headlamp Control Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HSWM(Heated Steering Wheel Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HUD(Head Up Display)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																																V
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPC(Instrument Panel Control Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PAM(Parking Aid Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PDM(Passenger's Door Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PSCM(Power Steering Control Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RACM(Rear Audio Control Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RCM(Restraint Control Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RGTM(Rear Gate/Trunk Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RTM(Radio Transceiver Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCCM(Streering Colume Control Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-E(Seat Control Module E)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-G(Seat Control Module G)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-H(Seat Control Module H)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SDD-L(Side Obstacle Detection Control Module Left)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SDD-R(Side Obstacle Detection Control Module Right)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TRM(Trailer Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)																																							V	V	V	V					
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																									V	V	V	V		
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																										V																				V	
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DCDC(DC to DC Convertal Control Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver Seat Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSP(Digital Signal Processing Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GWM(Gateway Module A)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HSWM(Heated Steering Wheel Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HUD(Head Up Display)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RACM(Rear Audio Control Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RTM(Radio Transceiver Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCCM(Streering Colume Control Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-E(Seat Control Module E)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-G(Seat Control Module G)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-H(Seat Control Module H)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																														
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)																																														
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																														
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																														
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																														
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																														
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	SYSTEM SEARCH																																																		
MONDEO	2012 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																		
MONDEO	2012 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	BCMii(Body Control Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																		
MONDEO	2012 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2012 MY	2.0L DIESEL	IPM-A(Image Processing Module A)																																																		
MONDEO	2012 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																		
MONDEO	2012 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)																																																		
MONDEO	2012 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																		
MONDEO	2012 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																		
MONDEO	2012 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	TRM(Trailer Module)																																																		
MONDEO	2012 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																		
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																		
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																		
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																		
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																		
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	SYSTEM SEARCH																																																		
MONDEO	2011 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																		
MONDEO	2011 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	BCMii(Body Control Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																		
MONDEO	2011 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2011 MY	2.0L DIESEL	IPM-A(Image Processing Module A)																																																		
MONDEO	2011 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																		
MONDEO	2011 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)																																																		
MONDEO	2011 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																		
MONDEO	2011 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																		
MONDEO	2011 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	TRM(Trailer Module)																																																		
MONDEO	2011 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	SYSTEM SEARCH																																																		
MONDEO	2011 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																																																		
MONDEO	2011 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2011 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																		
MONDEO	2011 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2011 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																		
MONDEO	2011 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	TRM(Trailer Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																		
MONDEO	2011 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																		
MONDEO	2011 MY	2.5L GASOLINE	SYSTEM SEARCH																																																		
MONDEO	2011 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																		
MONDEO	2011 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																		
MONDEO	2011 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2011 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																		
MONDEO	2011 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	TRM(Trailer Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																		
MONDEO	2011 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2010 MY	2.0L	DIESEL	SYSTEM SEARCH																																																	
MONDEO	2010 MY	2.0L	DIESEL	PCM(PowerTrain Control Module)																																				V	V											
MONDEO	2010 MY	2.0L	DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2010 MY	2.0L	DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	BCMii(Body Control Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2010 MY	2.0L	DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	DSM(Driver's Seat Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2010 MY	2.0L	DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	PBM(Parking Brake Control Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	PSCM(Power Steering Control Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	RFA(Remote Function Actuator)																																																	
MONDEO	2010 MY	2.0L	DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	TCM(Transmission Control Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	TRM(Trailer Module)																																																	
MONDEO	2010 MY	2.0L	DIESEL	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																		
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																		
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																		
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																	
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	SYSTEM SEARCH																																																		
MONDEO	2010 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																																																		
MONDEO	2010 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																		
MONDEO	2010 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2010 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																		
MONDEO	2010 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	TRM(Trailer Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																		
MONDEO	2010 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																		
MONDEO	2010 MY	2.5L GASOLINE	SYSTEM SEARCH																																																		
MONDEO	2010 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																		
MONDEO	2010 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2010 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																		
MONDEO	2010 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2010 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																		
MONDEO	2010 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	TRM(Trailer Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																		
MONDEO	2010 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																		
MONDEO	2009 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																	
MONDEO	2009 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2009 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2009 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																					V	V											
MONDEO	2009 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2009 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	BCMii(Body Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2009 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2009 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																	
MONDEO	2009 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	TRM(Trailer Module)																																																	
MONDEO	2009 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																					V	V											
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2009 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2009 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2009 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																		
MONDEO	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																		
MONDEO	2009 MY	2.0L DIESEL	TRM(Trailer Module)																																																		
MONDEO	2009 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	SYSTEM SEARCH																																																		
MONDEO	2009 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																																																		
MONDEO	2009 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																		
MONDEO	2009 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2009 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																		
MONDEO	2009 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	TRM(Trailer Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																		
MONDEO	2009 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																		
MONDEO	2009 MY	2.5L GASOLINE	SYSTEM SEARCH																																																		
MONDEO	2009 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																		
MONDEO	2009 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																		
MONDEO	2009 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2009 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2009 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																		
MONDEO	2009 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	TRM(Trailer Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																		
MONDEO	2009 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																		
MONDEO	2008 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	SYSTEM SEARCH																																																			
MONDEO	2008 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																						V	V												
MONDEO	2008 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																		
MONDEO	2008 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	BCMii(Body Control Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																		
MONDEO	2008 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2008 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2008 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	RCM(Restraint Control Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																		
MONDEO	2008 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	TRM(Trailer Module)																																																		
MONDEO	2008 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	SYSTEM SEARCH																																																		
MONDEO	2008 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																																																		
MONDEO	2008 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																		
MONDEO	2008 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2008 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																		
MONDEO	2008 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	TRM(Trailer Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																		
MONDEO	2008 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																		
MONDEO	2008 MY	2.5L GASOLINE	SYSTEM SEARCH																																																		
MONDEO	2008 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																		
MONDEO	2008 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2008 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																		
MONDEO	2008 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
MONDEO	2008 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																		
MONDEO	2008 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	TRM(Trailer Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																		
MONDEO	2008 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																		
MONDEO	2007 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																	
MONDEO	2007 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2007 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2007 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																					V	V											
MONDEO	2007 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2007 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	BCMii(Body Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2007 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2007 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																	
MONDEO	2007 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	TRM(Trailer Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2007 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2007 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2007 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2007 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2007 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2007 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2007 MY	2.5L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2007 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2007 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2007 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2007 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2007 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
MONDEO	2003 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2003 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																						V												
MONDEO	2003 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2003 MY	2.0L DIESEL	CSM(Central Security Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2003 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2003 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																	
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																	
MONDEO	2003 MY	2.0L DIESEL	ACM(Audio Control Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	CDP(Compact Disc Player)																																																	
MONDEO	2003 MY	2.0L DIESEL	GDM(Generic Display Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	NAV(Navigation System)																																																	
MONDEO	2003 MY	2.0L DIESEL	RETM(Rear Entertainment Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	ICU(Injector Control Unit)																																																	
MONDEO	2003 MY	2.0L DIESEL	PATS(Passive Anti Theft System)																																																	
MONDEO	2002 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2002 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																					V												
MONDEO	2002 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2002 MY	2.0L DIESEL	CSM(Central Security Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2002 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2002 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																	
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																	
MONDEO	2002 MY	2.0L DIESEL	ACM(Audio Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	CDP(Compact Disc Player)																																																	
MONDEO	2002 MY	2.0L DIESEL	GDM(Generic Display Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	NAV(Navigation System)																																																	
MONDEO	2002 MY	2.0L DIESEL	RETM(Rear Entertainment Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	ICU(Injector Control Unit)																																																	
MONDEO	2002 MY	2.0L DIESEL	PATS(Passive Anti Theft System)																																																	
MONDEO	2002 MY	2.0L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2002 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2002 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2002 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2002 MY	2.0L GASOLINE	GEM(Generic Electronic Module)																																																	
MONDEO	2002 MY	2.0L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2002 MY	2.0L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2001 MY	2.0L DIESEL	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	2001 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																		
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																		
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																		
MONDEO	2001 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																		
MONDEO	2001 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																		
MONDEO	2001 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																		
MONDEO	2001 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																		
MONDEO	2001 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																		
MONDEO	2001 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																		
MONDEO	2001 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																		
MONDEO	2001 MY	2.0L DIESEL	ACM(Audio Control Module)																																																		
MONDEO	2001 MY	2.0L GASOLINE	SYSTEM SEARCH																																																		
MONDEO	2001 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																		
MONDEO	2001 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																		
MONDEO	2001 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
MONDEO	2001 MY	2.0L GASOLINE	GEM(Generic Electronic Module)																																																		
MONDEO	2001 MY	2.0L GASOLINE	HCM(Headlamp Control Module)																																																		
MONDEO	2001 MY	2.0L GASOLINE	RCM(Restraint Control Module)																																																		
MONDEO	2000 MY	1.8L	SYSTEM SEARCH																																																		
MONDEO	2000 MY	1.8L	PCM(PowerTrain Control Module)																																																		
MONDEO	2000 MY	1.8L	ABS(Anti-Lock Brake System)																																																		
MONDEO	2000 MY	1.8L	CSM(Central Security Module)																																																		
MONDEO	2000 MY	1.8L DIESEL	SYSTEM SEARCH																																																		
MONDEO	2000 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																		
MONDEO	2000 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																		
MONDEO	2000 MY	1.8L DIESEL	CSM(Central Security Module)																																																		
MONDEO	2000 MY	1.8L DIESEL	Passive Antitheft																																																		
MONDEO	2000 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																		
MONDEO	2000 MY	2.0L	SYSTEM SEARCH																																																		
MONDEO	2000 MY	2.0L	PCM(PowerTrain Control Module)																																																		
MONDEO	2000 MY	2.0L	ABS(Anti-Lock Brake System)																																																		
MONDEO	2000 MY	2.0L	CSM(Central Security Module)																																																		
MONDEO	2000 MY	2.5L	SYSTEM SEARCH																																																		
MONDEO	2000 MY	2.5L	PCM(PowerTrain Control Module)																																																		
MONDEO	2000 MY	2.5L	ABS(Anti-Lock Brake System)																																																		
MONDEO	2000 MY	2.5L	CSM(Central Security Module)																																																		
MONDEO	1999 MY	1.8L	SYSTEM SEARCH																																																		
MONDEO	1999 MY	1.8L	PCM(PowerTrain Control Module)																																																		
MONDEO	1999 MY	1.8L	ABS(Anti-Lock Brake System)																																																		
MONDEO	1999 MY	1.8L	CSM(Central Security Module)																																																		
MONDEO	1999 MY	1.8L DIESEL	SYSTEM SEARCH																																																		
MONDEO	1999 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MONDEO	1999 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																		
MONDEO	1999 MY	1.8L DIESEL	CSM(Central Security Module)																																																		
MONDEO	1999 MY	1.8L DIESEL	Passive Antitheft																																																		
MONDEO	1999 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																		
MONDEO	1999 MY	2.0L	SYSTEM SEARCH																																																		
MONDEO	1999 MY	2.0L	PCM(PowerTrain Control Module)																																																		
MONDEO	1999 MY	2.0L	ABS(Anti-Lock Brake System)																																																		
MONDEO	1999 MY	2.0L	CSM(Central Security Module)																																																		
MONDEO	1999 MY	2.5L	SYSTEM SEARCH																																																		
MONDEO	1999 MY	2.5L	PCM(PowerTrain Control Module)																																																		
MONDEO	1999 MY	2.5L	ABS(Anti-Lock Brake System)																																																		
MONDEO	1999 MY	2.5L	CSM(Central Security Module)																																																		
MONDEO	1998 MY	1.8L	SYSTEM SEARCH																																																		
MONDEO	1998 MY	1.8L	PCM(PowerTrain Control Module)																																																		
MONDEO	1998 MY	1.8L	ABS(Anti-Lock Brake System)																																																		
MONDEO	1998 MY	1.8L	CSM(Central Security Module)																																																		
MONDEO	1998 MY	1.8L DIESEL	SYSTEM SEARCH																																																		
MONDEO	1998 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																		
MONDEO	1998 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																		
MONDEO	1998 MY	1.8L DIESEL	CSM(Central Security Module)																																																		
MONDEO	1998 MY	1.8L DIESEL	Passive Antitheft																																																		
MONDEO	1998 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																		
MONDEO	1998 MY	2.0L	SYSTEM SEARCH																																																		
MONDEO	1998 MY	2.0L	PCM(PowerTrain Control Module)																																																		
MONDEO	1998 MY	2.0L	ABS(Anti-Lock Brake System)																																																		
MONDEO	1998 MY	2.0L	CSM(Central Security Module)																																																		
MONDEO	1998 MY	2.5L	SYSTEM SEARCH																																																		
MONDEO	1998 MY	2.5L	PCM(PowerTrain Control Module)																																																		
MONDEO	1998 MY	2.5L	ABS(Anti-Lock Brake System)																																																		
MONDEO	1998 MY	2.5L	CSM(Central Security Module)																																																		
MONDEO	1997 MY	1.8L	PCM(PowerTrain Control Module)																																																		
MONDEO	1997 MY	1.8L	ABS(Anti-Lock Brake System)																																																		
MONDEO	1997 MY	1.8L DIESEL	SYSTEM SEARCH																																																		
MONDEO	1997 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																		
MONDEO	1997 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																		
MONDEO	1997 MY	1.8L DIESEL	Passive Antitheft																																																		
MONDEO	1997 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																		
MONDEO	1997 MY	2.0L	PCM(PowerTrain Control Module)																																																		
MONDEO	1997 MY	2.0L	ABS(Anti-Lock Brake System)																																																		
MONDEO	1997 MY	2.5L	PCM(PowerTrain Control Module)																																																		
MONDEO	1997 MY	2.5L	ABS(Anti-Lock Brake System)																																																		
MOUNTAINEER	2010 MY	4.6L	SYSTEM SEARCH																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MOUNTAINEER	2010 MY	4.6L	PCM(Powertrain Control Module)																																																		
MOUNTAINEER	2010 MY	4.6L	TCM(Transmission Control Module)																																																		
MOUNTAINEER	2010 MY	4.6L	4X4(4x4 Control Module)																																																		
MOUNTAINEER	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																		
MOUNTAINEER	2010 MY	4.6L	ACM(Audio Control Module)																																																		
MOUNTAINEER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																		
MOUNTAINEER	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																		
MOUNTAINEER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																		
MOUNTAINEER	2010 MY	4.6L	DSM(Driver's Seat Module)																																																		
MOUNTAINEER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
MOUNTAINEER	2010 MY	4.6L	IC(Instrument Cluster)																																																		
MOUNTAINEER	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																		
MOUNTAINEER	2010 MY	4.6L	PAM(Parking Aid Module)																																																		
MOUNTAINEER	2010 MY	4.6L	PRB(Power Running Board)																																																		
MOUNTAINEER	2010 MY	4.6L	RCM(Restraint Control Module)																																																		
MOUNTAINEER	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																		
MOUNTAINEER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																		
MOUNTAINEER	2009 MY	4.6L	SYSTEM SEARCH																																																		
MOUNTAINEER	2009 MY	4.6L	PCM(Powertrain Control Module)																																																		
MOUNTAINEER	2009 MY	4.6L	TCM(Transmission Control Module)																																																		
MOUNTAINEER	2009 MY	4.6L	4X4(4x4 Control Module)																																																		
MOUNTAINEER	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																		
MOUNTAINEER	2009 MY	4.6L	ACM(Audio Control Module)																																																		
MOUNTAINEER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																		
MOUNTAINEER	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																		
MOUNTAINEER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																		
MOUNTAINEER	2009 MY	4.6L	DSM(Driver's Seat Module)																																																		
MOUNTAINEER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
MOUNTAINEER	2009 MY	4.6L	IC(Instrument Cluster)																																																		
MOUNTAINEER	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																		
MOUNTAINEER	2009 MY	4.6L	PAM(Parking Aid Module)																																																		
MOUNTAINEER	2009 MY	4.6L	PRB(Power Running Board)																																																		
MOUNTAINEER	2009 MY	4.6L	RCM(Restraint Control Module)																																																		
MOUNTAINEER	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																		
MOUNTAINEER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																		
MUSTANG	4.0L V6 SOHC			SYSTEM SEARCH																																																	
MUSTANG	4.0L V6 SOHC			PCM(Powertrain Control Module)																																																		
MUSTANG	4.0L V6 SOHC			ABS(Anti-Lock Brake System)																																																		
MUSTANG	4.0L V6 SOHC			ACM(Audio Control Module)																																																		
MUSTANG	4.0L V6 SOHC			APIM(Accessory Protocol Interface Module)																																																		
MUSTANG	4.0L V6 SOHC			GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
MUSTANG	4.0L V6 SOHC			RCM(Restraint Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
MUSTANG	4.0L V6 SOHC			SDARS(Satellite Digital Audio Receiver System)																																																	
MUSTANG	4.0L V6 SOHC			IC(Instrument Cluster)																																																	
TAURUS	2011 MY	3.5L	SYSTEM SEARCH																																																		
TAURUS	2011 MY	3.5L	PCM(PowerTrain Control Module)																																																		
TAURUS	2011 MY	3.5L	4X4(4x4 Control Module)																																																		
TAURUS	2011 MY	3.5L	ABS(Anti-Lock Brake System)																																																		
TAURUS	2011 MY	3.5L	ACM(Audio Control Module)																																																		
TAURUS	2011 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																		
TAURUS	2011 MY	3.5L	C-CM(Cruise Control Module)																																																		
TAURUS	2011 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																		
TAURUS	2011 MY	3.5L	DDM(Driver's Door Module)																																																		
TAURUS	2011 MY	3.5L	DSM(Driver's Seat Module)																																																		
TAURUS	2011 MY	3.5L	DSP(Digital Signal Processing Module)																																																		
TAURUS	2011 MY	3.5L	FCIM(Front Controls Interface Module)																																																		
TAURUS	2011 MY	3.5L	FDIM(Front Display Interface Module)																																																		
TAURUS	2011 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
TAURUS	2011 MY	3.5L	GPSM(Global Positioning System Module)																																																		
TAURUS	2011 MY	3.5L	HCM(Headlamp Control Module)																																																		
TAURUS	2011 MY	3.5L	HCM-2(Headlamp Control Module2)																																																		
TAURUS	2011 MY	3.5L	HUD(Head Up Display)																																																		
TAURUS	2011 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																		
TAURUS	2011 MY	3.5L	ILCM(Interior Lighting Control Module)																																																		
TAURUS	2011 MY	3.5L	IPC(Instrument Panel Control Module)																																																		
TAURUS	2011 MY	3.5L	OCSM(Occupant Classification System Module)																																																		
TAURUS	2011 MY	3.5L	PAM(Parking Aid Module)																																																		
TAURUS	2011 MY	3.5L	PSCM(Power Steering Control Module)																																																		
TAURUS	2011 MY	3.5L	RCM(Restraint Control Module)																																																		
TAURUS	2011 MY	3.5L	RETM(Rear Entertainment Module)																																																		
TAURUS	2011 MY	3.5L	RFA(Remote Function Actuator)																																																		
TAURUS	2011 MY	3.5L	SASM(Steering Angle Sensor Module)																																																		
TAURUS	2011 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																		
TAURUS	2011 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																		
TAURUS	2010 MY	3.5L	SYSTEM SEARCH																																																		
TAURUS	2010 MY	3.5L	PCM(PowerTrain Control Module)																																																		
TAURUS	2010 MY	3.5L	4X4(4x4 Control Module)																																																		
TAURUS	2010 MY	3.5L	ABS(Anti-Lock Brake System)																																																		
TAURUS	2010 MY	3.5L	ACM(Audio Control Module)																																																		
TAURUS	2010 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																		
TAURUS	2010 MY	3.5L	C-CM(Cruise Control Module)																																																		
TAURUS	2010 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																		
TAURUS	2010 MY	3.5L	DDM(Driver's Door Module)																																																		
TAURUS	2010 MY	3.5L	DSM(Driver's Seat Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
TAURUS	2010 MY	3.5L	DSP(Digital Signal Processing Module)																																																		
TAURUS	2010 MY	3.5L	FCIM(Front Controls Interface Module)																																																		
TAURUS	2010 MY	3.5L	FDIM(Front Display Interface Module)																																																		
TAURUS	2010 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
TAURUS	2010 MY	3.5L	GPSM(Global Positioning System Module)																																																		
TAURUS	2010 MY	3.5L	HCM(Headlamp Control Module)																																																		
TAURUS	2010 MY	3.5L	HCM-2(Headlamp Control Module2)																																																		
TAURUS	2010 MY	3.5L	HUD(Head Up Display)																																																		
TAURUS	2010 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																		
TAURUS	2010 MY	3.5L	ILCM(Interior Lighting Control Module)																																																		
TAURUS	2010 MY	3.5L	IPC(Instrument Panel Control Module)																																																		
TAURUS	2010 MY	3.5L	OCSM(Occupant Classification System Module)																																																		
TAURUS	2010 MY	3.5L	PAM(Parking Aid Module)																																																		
TAURUS	2010 MY	3.5L	PSCM(Power Steering Control Module)																																																		
TAURUS	2010 MY	3.5L	RCM(Restraint Control Module)																																																		
TAURUS	2010 MY	3.5L	RETM(Rear Entertainment Module)																																																		
TAURUS	2010 MY	3.5L	RFA(Remote Function Actuator)																																																		
TAURUS	2010 MY	3.5L	SASM(Steering Angle Sensor Module)																																																		
TAURUS	2010 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																		
TAURUS	2010 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																		
TAURUS	2009 MY	3.5L	SYSTEM SEARCH																																																		
TAURUS	2009 MY	3.5L	PCM(PowerTrain Control Module)																																																		
TAURUS	2009 MY	3.5L	4X4(4x4 Control Module)																																																		
TAURUS	2009 MY	3.5L	ABS(Anti-Lock Brake System)																																																		
TAURUS	2009 MY	3.5L	ACM(Audio Control Module)																																																		
TAURUS	2009 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																		
TAURUS	2009 MY	3.5L	C-CM(Cruise Control Module)																																																		
TAURUS	2009 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																		
TAURUS	2009 MY	3.5L	DDM(Driver's Door Module)																																																		
TAURUS	2009 MY	3.5L	DSM(Driver's Seat Module)																																																		
TAURUS	2009 MY	3.5L	DSP(Digital Signal Processing Module)																																																		
TAURUS	2009 MY	3.5L	FCIM(Front Controls Interface Module)																																																		
TAURUS	2009 MY	3.5L	FDIM(Front Display Interface Module)																																																		
TAURUS	2009 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
TAURUS	2009 MY	3.5L	GPSM(Global Positioning System Module)																																																		
TAURUS	2009 MY	3.5L	HCM(Headlamp Control Module)																																																		
TAURUS	2009 MY	3.5L	HCM-2(Headlamp Control Module2)																																																		
TAURUS	2009 MY	3.5L	HUD(Head Up Display)																																																		
TAURUS	2009 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																		
TAURUS	2009 MY	3.5L	ILCM(Interior Lighting Control Module)																																																		
TAURUS	2009 MY	3.5L	IPC(Instrument Panel Control Module)																																																		
TAURUS	2009 MY	3.5L	OCSM(Occupant Classification System Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
TAURUS	2009 MY	3.5L	PAM(Parking Aid Module)																																																		
TAURUS	2009 MY	3.5L	PSCM(Power Steering Control Module)																																																		
TAURUS	2009 MY	3.5L	RCM(Restraint Control Module)																																																		
TAURUS	2009 MY	3.5L	RETM(Rear Entertainment Module)																																																		
TAURUS	2009 MY	3.5L	RFA(Remote Function Actuator)																																																		
TAURUS	2009 MY	3.5L	SASM(Steering Angle Sensor Module)																																																		
TAURUS	2009 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																		
TAURUS	2009 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																		
TAURUS	2008 MY	3.5L	SYSTEM SEARCH																																																		
TAURUS	2008 MY	3.5L	PCM(PowerTrain Control Module)																																																		
TAURUS	2008 MY	3.5L	4X4(4x4 Control Module)																																																		
TAURUS	2008 MY	3.5L	ABS(Anti-Lock Brake System)																																																		
TAURUS	2008 MY	3.5L	ACM(Audio Control Module)																																																		
TAURUS	2008 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																		
TAURUS	2008 MY	3.5L	C-CM(Cruise Control Module)																																																		
TAURUS	2008 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																																		
TAURUS	2008 MY	3.5L	DDM(Driver's Door Module)																																																		
TAURUS	2008 MY	3.5L	DSM(Driver's Seat Module)																																																		
TAURUS	2008 MY	3.5L	DSP(Digital Signal Processing Module)																																																		
TAURUS	2008 MY	3.5L	FCIM(Front Controls Interface Module)																																																		
TAURUS	2008 MY	3.5L	FDIM(Front Display Interface Module)																																																		
TAURUS	2008 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																		
TAURUS	2008 MY	3.5L	GPSM(Global Positioning System Module)																																																		
TAURUS	2008 MY	3.5L	HCM(Headlamp Control Module)																																																		
TAURUS	2008 MY	3.5L	HCM-2(Headlamp Control Module2)																																																		
TAURUS	2008 MY	3.5L	HUD(Head Up Display)																																																		
TAURUS	2008 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																		
TAURUS	2008 MY	3.5L	ILCM(Interior Lighting Control Module)																																																		
TAURUS	2008 MY	3.5L	IPC(Instrument Panel Control Module)																																																		
TAURUS	2008 MY	3.5L	OCSM(Occupant Classification System Module)																																																		
TAURUS	2008 MY	3.5L	PAM(Parking Aid Module)																																																		
TAURUS	2008 MY	3.5L	PSCM(Power Steering Control Module)																																																		
TAURUS	2008 MY	3.5L	RCM(Restraint Control Module)																																																		
TAURUS	2008 MY	3.5L	RETM(Rear Entertainment Module)																																																		
TAURUS	2008 MY	3.5L	RFA(Remote Function Actuator)																																																		
TAURUS	2008 MY	3.5L	SASM(Steering Angle Sensor Module)																																																		
TAURUS	2008 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																		
TAURUS	2008 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																		
TAURUS	1998 MY	SYSTEM SEARCH																																																		
TAURUS	1998 MY	PCM(PowerTrain Control Module)																																																		
TAURUS	1998 MY	ABS(Anti-Lock Brake System)																																																		
TAURUS	1998 MY	RCM(Restraint Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
TAURUS	1998 MY	RIM(Remote Immobilizer Module)																																																			
TAURUS	1997 MY	SYSTEM SEARCH																																																			
TAURUS	1997 MY	PCM(PowerTrain Control Module)																																																			
TAURUS	1997 MY	ABS(Anti-Lock Brake System)																																																			
TAURUS	1997 MY	RCM(Restraint Control Module)																																																			
TAURUS	1997 MY	RIM(Remote Immobilizer Module)																																																			
TAURUS	1996 MY	SYSTEM SEARCH																																																			
TAURUS	1996 MY	PCM(PowerTrain Control Module)																																																			
TAURUS	1996 MY	ABS(Anti-Lock Brake System)																																																			
TAURUS	1996 MY	RCM(Restraint Control Module)																																																			
TAURUS	1996 MY	RIM(Remote Immobilizer Module)																																																			
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	SYSTEM SEARCH																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PCM(PowerTrain Control Module)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	TCM(Transmission Control Module)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ABS(Anti-Lock Brake System)																											V		V																				
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ACM(Audio Control Module)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	APIM(Accessory Protocol Interface Module)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	BEM(Body Electronic Module)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	FCIM(Front Controls Interface Module)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GPSM(Global Positioning System Module)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GWM(Gateway Module A)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	HIM(HVAC Integrated Module)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	IPC(Instrument Panel Control Module)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PAM(Parking Aid Module)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PSCM(Power Steering Control Module)	V																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	RCM(Restraint Control Module)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	SYSTEM SEARCH																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	PCM(Powertrain Control Module)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	TCM(Transmission Control Module)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)																											V		V																				
TERRITORY	2010~	4.0L GASOLINE	SY	ACM(Audio Control Module)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	PSCM(Power Steering Control Module)	V																																																
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	HIM(HVAC Integrated Module)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)																																																	
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
TERRITORY	2010~	4.0L GASOLINE	SY	FDIM(Front Display Interface Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	SYSTEM SEARCH																																																
TERRITORY	2010~	2.7L DIESEL	SZ	PCM(Powertrain Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	ABS(Anti-Lock Brake System)																											V		V																			
TERRITORY	2010~	2.7L DIESEL	SZ	ACM(Audio Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	AWD(All Wheel Drive Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	BEM(Body Electronic Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	FDIM(Front Display Interface Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	HIM(HVAC Intergrated Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	IPC(Instrument Panel Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	PAM(Parking Aid Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	PSCM(Power Steering Control Module)	V																																															
TERRITORY	2010~	2.7L DIESEL	SZ	RCM(Restraint Control Module)																																																
TERRITORY	2010~	2.7L DIESEL	SZ	TCM(Transmission Control Module)																																																
TERRITORY	2009~2010	SYSTEM SEARCH																																																		
TERRITORY	2009~2010	PCM(PowerTrain Control Module)																																																		
TERRITORY	2009~2010	TCM(Transmission Control Module)																																																		
TERRITORY	2009~2010	ABS(Anti-Lock Brake System)																																																		
TERRITORY	2009~2010	RCM(Restraint Control Module)																																																		
TERRITORY	2009~2010	BEM(Body Electronic Module)																																																		
TERRITORY	2009~2010	IC(Instrument Cluster)																																																		
TERRITORY	2009~2010	HIM(HVAC Integrated Module)																																																		
TERRITORY	2009~2010	ACM(Audio Control Module)																																																		
TERRITORY	2005~2009	SYSTEM SEARCH																																																		
TERRITORY	2005~2009	PCM(PowerTrain Control Module)																																																		
TERRITORY	2005~2009	TCM(Transmission Control Module)																																																		
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)																																																		
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)																																																		
TERRITORY	2005~2009	RCM(Restraint Control Module)																																																		
TERRITORY	2005~2009	BEM(Body Electronic Module)																																																		
TERRITORY	2005~2009	IC(Instrument Cluster)																																																		
TERRITORY	2005~2009	HIM(HVAC Integrated Module)																																																		
TERRITORY	2005~2009	ACM(Audio Control Module)																																																		
TERRITORY	2004~2005	SYSTEM SEARCH																																																		
TERRITORY	2004~2005	PCM(PowerTrain Control Module)																																																		
TERRITORY	2004~2005	ABS(Anti-Lock Brake System)																																																		
TERRITORY	2004~2005	RCM(Restraint Control Module)																																																		
TERRITORY	2004~2005	BEM(Body Electronic Module)																																																		
TERRITORY	2004~2005	IC(Instrument Cluster)																																																		
TERRITORY	2004~2005	HIM(HVAC Integrated Module)																																																		
TERRITORY	2004~2005	HIM(HVAC Integrated Module)																																																		
TERRITORY	2004~2005	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
TERRITORY	2004~2005	PAM(Parking Aid Module)																																																		
TRANSIT	1.6L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	1.6L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																		
TRANSIT	1.6L DIESEL	ACM(Audio Control Module)																																																		
TRANSIT	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
TRANSIT	1.6L DIESEL	APIM(Accessory Protocol Interface Module)																																																		
TRANSIT	1.6L DIESEL	BCMii(Body Control Module)																																	V	V																
TRANSIT	1.6L DIESEL	DDM(Driver's Door Module)																																																		
TRANSIT	1.6L DIESEL	FCIM(Front Controls Interface Module)																																																		
TRANSIT	1.6L DIESEL	FDSM(Front Distance Sensing Module)																																																		
TRANSIT	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)																																																		
TRANSIT	1.6L DIESEL	GPSM(Global Positioning System Module)																																																		
TRANSIT	1.6L DIESEL	HCM(Headlamp Control Module)																																																		
TRANSIT	1.6L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
TRANSIT	1.6L DIESEL	IPM-B(Image Processing Module B)																																																		
TRANSIT	1.6L DIESEL	IPC(Instrument Panel Control Module)																																																		
TRANSIT	1.6L DIESEL	PAM(Parking Aid Module)																																																		
TRANSIT	1.6L DIESEL	PDM(Passenger's Door Module)																																																		
TRANSIT	1.6L DIESEL	PSCM(Power Steering Control Module)																																				V														
TRANSIT	1.6L DIESEL	RCM(Restraint Control Module)																																																		
TRANSIT	1.6L DIESEL	SASM(Steering Angle Sensor Module)																																																		
TRANSIT	1.6L DIESEL	TRM(Trailer Module)																																																		
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																			V	V	V												
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)																																			V	V	V												
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)																																																	
TRANSIT	2.0L	SYSTEM SEARCH																																																			
TRANSIT	2.0L	PCM(PowerTrain Control Module)																																																			
TRANSIT	2.0L	PATS(Passive Anti Theft System)																																																			
TRANSIT	2.0L	ASM(Auto Shift Manual)																																																			
TRANSIT	2.0L	ABS(Anti-Lock Brake System)																																																			
TRANSIT	2.0L	HEC(Hybrid Electrical Cluster)																																																			
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SYSTEM SEARCH																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ACM(Audio Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	APIM(Accessory Protocol Interface Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	AHCM(Auxiliary Heater Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	CCMii(Cruise Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FCDIM(Front Control/Display Interface Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	GPSM(Global Positioning System Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	HCM(Headlamp Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-A(Image Processing Module A)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-B(Image Processing Module B)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FFH(Fuel Fired Coolant Heating Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PRB(Power Running Board)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SRM(Speech Recognition Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SASM(Steering Angle Sensor Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TBC(Trailer Brake Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TRM(Trailer Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SYSTEM SEARCH																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	APIM(Accessory Protocol Interface Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	AHCM(Auxiliary Heater Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	CCMii(Cruise Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FCDIM(Front Control/Display Interface Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	GPSM(Global Positioning System Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	HCM(Headlamp Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-A(Image Processing Module A)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-B(Image Processing Module B)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FFH(Fuel Fired Coolant Heating Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PRB(Power Running Board)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SRM(Speech Recognition Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SASM(Steering Angle Sensor Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TBC(Trailer Brake Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TRM(Trailer Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	SYSTEM SEARCH																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PATS(Passive Anti Theft System)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ASM(Auto Shift Manual)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	HEC(Hybrid Electrical Cluster)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	IPC(Instrument Panel Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	BCMii(Body Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	CSM(Central Security Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ACM(Audio Control Module)																																																	
TRANSIT	2.3L DIESEL	SYSTEM SEARCH																																																			
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)																																																			
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)																																																			
TRANSIT	2.3L DIESEL	PATS(Passive Anti Theft System)																																																			
TRANSIT	2.3L DIESEL	ASM(Auto Shift Manual)																																																			
TRANSIT	2.3L DIESEL	ABS(Anti-Lock Brake System)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
TRANSIT	2.3L DIESEL	RCM(Restraint Control Module)																																																			
TRANSIT	2.3L DIESEL	HEC(Hybrid Electrical Cluster)																																																			
TRANSIT	2.3L DIESEL	IPC(Instrument Panel Control Module)																																																			
TRANSIT	2.3L DIESEL	BCMii(Body Control Module)																																																			
TRANSIT	2.3L DIESEL	ACM(Audio Control Module)																																																			
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																																		
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																		
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)																																																		
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	BCMii(Body Control Module)																																																		
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																		
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	IPC(Instrument Panel Control Module)																																																		
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)																																																		
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																		
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)																																																		
TRANSIT	2.4L DIESEL	SYSTEM SEARCH																																																			
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)																																																			
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)																																																			
TRANSIT	2.4L DIESEL	PATS(Passive Anti Theft System)																																																			
TRANSIT	2.4L DIESEL	ASM(Auto Shift Manual)																																																			
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)																																																			
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)																																																			
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)																																																			
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)																																																			
TRANSIT	2.4L DIESEL	HEC(Hybrid Electrical Cluster)																																																			
TRANSIT	2.4L DIESEL	IPC(Instrument Panel Control Module)																																																			
TRANSIT	2.4L DIESEL	BCMii(Body Control Module)																																																			
TRANSIT	2.4L DIESEL	CSM(Central Security Module)																																																			
TRANSIT	2.4L DIESEL	ACM(Audio Control Module)																																																			
TRANSIT	2.5L DIESEL	SYSTEM SEARCH																																																			
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)																																																			
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)																																																			
TRANSIT	2.5L DIESEL	PATS(Passive Anti Theft System)																																																			
TRANSIT	2.5L DIESEL	ASM(Auto Shift Manual)																																																			
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																																																		
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																																																		
TRANSIT	2.5L DIESEL	RCM(Restraint Control Module)																																																			
TRANSIT	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																																																			
TRANSIT	2.5L DIESEL	CSM(Central Security Module)																																																			
TRANSIT	2.5L DIESEL	Passive Antitheft																																																			
TRANSIT	2.5L DIESEL	RIM(Remote Immobilizer Module)																																																			
TRANSIT	2.5L DIESEL	ACM(Audio Control Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
TRANSIT	3.2L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	3.2L DIESEL	ABS(Anti-Lock Brake System)																																																		
TRANSIT	3.2L DIESEL	ACM(Audio Control Module)																																																		
TRANSIT	3.2L DIESEL	BCMii(Body Control Module)																																																		
TRANSIT	3.2L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																		
TRANSIT	3.2L DIESEL	IPC(Instrument Panel Control Module)																																																		
TRANSIT	3.2L DIESEL	PAM(Parking Aid Module)																																																		
TRANSIT	3.2L DIESEL	RCM(Restraint Control Module)																																																		
TRANSIT	3.2L DIESEL	SRM(Speech Recognition Module)																																																		
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																			V	V	V											
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)																																			V	V	V											
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)																																																
RANGER	2.2 Diesel	SYSTEM SEARCH																																																		
RANGER	2.2 Diesel	PCM(PowerTrain Control Module)																																																		
RANGER	2.2 Diesel	ABS(Anti-Lock Brake System)																																V																		
RANGER	2.2 Diesel	ACM(Audio Control Module)																																																		
RANGER	2.2 Diesel	BCMii(Body Control Module)																																	V																		
RANGER	2.2 Diesel	DDM(Driver's Door Module)																																																		
RANGER	2.2 Diesel	FCDIM(Front Control/Display Interface Module)																																																		
RANGER	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
RANGER	2.2 Diesel	IPC(Instrument Panel Control Module)																																																			
RANGER	2.2 Diesel	PAM(Parking Aid Module)																																																			
RANGER	2.2 Diesel	PDM(Passenger's Door Module)																																																			
RANGER	2.2 Diesel	RCM(Restraint Control Module)																																																			
RANGER	2.2 Diesel	SRM(Speech Recognition Module)																																																			
RANGER	2.2 Diesel	TBM(Tracking And Blocking Module)																																																			
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																			
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																			
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																			
RANGER	2.2 Diesel	TRM(Trailer Module)																																																			
RANGER	2.2 Diesel	PATS(Passive anti theft system)-BETA																																																			
RANGER	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																																			
RANGER	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																																																			
RANGER	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																																																			
RANGER	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																																																			
RANGER	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																																																			
RANGER	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)-BETA																																																			
RANGER	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																																			
RANGER	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																																																			
RANGER	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																																																			
RANGER	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																																																			
RANGER	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																																																			
RANGER	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)-BETA																																																			
RANGER	3.2 Diesel	~ 2015	SYSTEM SEARCH																																																		
RANGER	3.2 Diesel	~ 2015	PCM(PowerTrain Control Module)																																								V										
RANGER	3.2 Diesel	~ 2015	ABS(Anti-Lock Brake System)																															V																			
RANGER	3.2 Diesel	~ 2015	ACM(Audio Control Module)																																																		
RANGER	3.2 Diesel	~ 2015	BCMii(Body Control Module)																																																		
RANGER	3.2 Diesel	~ 2015	DDM(Driver's Door Module)																																																		
RANGER	3.2 Diesel	~ 2015	FCDIM(Front Control/Display Interface Module)																																																		
RANGER	3.2 Diesel	~ 2015	HVAC(Heating Ventilation Air Conditioning)																																																		
RANGER	3.2 Diesel	~ 2015	IPC(Instrument Panel Control Module)																																																		
RANGER	3.2 Diesel	~ 2015	PAM(Parking Aid Module)																																																		
RANGER	3.2 Diesel	~ 2015	PDM(Passenger's Door Module)																																																		
RANGER	3.2 Diesel	~ 2015	RCM(Restraint Control Module)																																																		
RANGER	3.2 Diesel	~ 2015	SRM(Speech Recognition Module)																																																		
RANGER	3.2 Diesel	~ 2015	TBM(Tracking And Blocking Module)																																																		
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																		
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																		
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																		
RANGER	3.2 Diesel	~ 2015	TRM(Trailer Module)																																																		
RANGER	3.2 Diesel	~ 2015	PATS(Passive anti theft system)-BETA																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
RANGER	3.2 Diesel	2015 ~	SYSTEM SEARCH																																																		
RANGER	3.2 Diesel	2015 ~	PCM(PowerTrain Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	TCM(Transmission Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	ABS(Anti-Lock Brake System)																																																		
RANGER	3.2 Diesel	2015 ~	ACM(Audio Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	APIM(Accessory Protocol Interface Module)																																																		
RANGER	3.2 Diesel	2015 ~	ATCM(All Terrain Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	BCM(Body Control Module)																											V				V		V																
RANGER	3.2 Diesel	2015 ~	C-CM(Cruise Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	DDM(Driver's Door Module)																																																		
RANGER	3.2 Diesel	2015 ~	FCDIM(Front Control/Display Interface Module)																																																		
RANGER	3.2 Diesel	2015 ~	FCIM(Front Controls Interface Module)																																																		
RANGER	3.2 Diesel	2015 ~	GPSM(Global Positioning System Module)																																																		
RANGER	3.2 Diesel	2015 ~	GWM(Gateway Module A)																																																		
RANGER	3.2 Diesel	2015 ~	HCM(Headlamp Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	HUD(Head Up Display)																																																		
RANGER	3.2 Diesel	2015 ~	IPC(Instrument Panel Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	IPM-A(Image Processing Module A)																																																		V
RANGER	3.2 Diesel	2015 ~	PAM(Parking Aid Module)																																																		
RANGER	3.2 Diesel	2015 ~	PDM(Passenger's Door Module)																																																		
RANGER	3.2 Diesel	2015 ~	PSCM(Power Steering Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	RCM(Restraint Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	RGTM(Rear Gate/Trunk Module)																																																		
RANGER	3.2 Diesel	2015 ~	RTM(Radio Transceiver Module)																																																		
RANGER	3.2 Diesel	2015 ~	SCCM(Streering Colume Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	TCU(Telemetic Control Unit Module)																																																		
RANGER	3.2 Diesel	2015 ~	TRM(Trailer Module)																																																		
RANGER	2.5 Gasoline	SYSTEM SEARCH																																																			
RANGER	2.5 Gasoline	PCM(PowerTrain Control Module)																																																			
RANGER	2.5 Gasoline	ABS(Anti-Lock Brake System)																																V																			
RANGER	2.5 Gasoline	ACM(Audio Control Module)																																																			
RANGER	2.5 Gasoline	BCMii(Body Control Module)																																	V																			
RANGER	2.5 Gasoline	DDM(Driver's Door Module)																																																			
RANGER	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																																																			
RANGER	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																																																			
RANGER	2.5 Gasoline	IPC(Instrument Panel Control Module)																																																			
RANGER	2.5 Gasoline	PAM(Parking Aid Module)																																																			
RANGER	2.5 Gasoline	PDM(Passenger's Door Module)																																																			
RANGER	2.5 Gasoline	RCM(Restraint Control Module)																																																			
RANGER	2.5 Gasoline	SRM(Speech Recognition Module)																																																			
RANGER	2.5 Gasoline	TBM(Tracking And Blocking Module)																																																			
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																			
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																			
RANGER	2.5 Gasoline	TRM(Trailer Module)																																																			
RANGER	2.5 Gasoline	PATS(Passive anti theft system)-BETA																																																			
BETA-TEST	FOCUS-1.6L Zetec Rocam	SYSTEM SEARCH																																																			
BETA-TEST	FOCUS-1.6L Zetec Rocam	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FOCUS-1.6L Zetec Rocam	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FOCUS-1.6L Zetec Rocam	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FOCUS-1.6L Zetec Rocam	GEM(Generic Electronic Module)																																																			
BETA-TEST	FOCUS-1.6L Zetec Rocam	HCM(Headlamp Control Module)																																																			
BETA-TEST	FOCUS-1.6L Zetec Rocam	MC(Message Center)																																																			
BETA-TEST	FOCUS-1.6L Zetec Rocam	RCM(Restraint Control Module)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SYSTEM SEARCH																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ACM(Audio Control Module)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CDP(Compact Disc Player)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CMR(Camera Module Rear)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	D_DCU(Driver Door Control Unit)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EPS(Electronic Power Steering)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	FFH(Fuel Fired Coolant Heating Module)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	HCM(Headlamp Control Module)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	IC(Instrument Cluster)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PAM(Parking Aid Module)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PDM(Passenger's Door Module)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RCM(Restraint Control Module)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RETM(Rear Entertainment Module)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RKE(Remote Keyless Entry)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GDM(Generic Display Module)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	NAV(Navigation System)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RL_DCU(Rear Left Door Control Unit)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RR_DCU(Rear Right Door Control Unit)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)																																																			
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	TCM(Transmission Control Module)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	SYSTEM SEARCH																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ACM(Audio Control Module)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CDP(Compact Disc Player)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CMR(Camera Module Rear)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	D_DCU(Driver Door Control Unit)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EPS(Electronic Power Steering)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FACM(Fuel Additive Control Module)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	GEM(Generic Electronic Module)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	HCM(Headlamp Control Module)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	IC(Instrument Cluster)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PAM(Parking Aid Module)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PDM(Passenger's Door Module)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RCM(Restraint Control Module)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RETM(Rear Entertainment Module)																																																			
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RKE(Remote Keyless Entry)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SYSTEM SEARCH																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ACM(Audio Control Module)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	CDP(Compact Disc Player)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EPS(Electronic Power Steering)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GDM(Generic Display Module)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GEM(Generic Electronic Module)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	IC(Instrument Cluster)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	NAV(Navigation System)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PAM(Parking Aid Module)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PDM(Passenger's Door Module)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SRM(Speech Recognition Module)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	HCM(Headlamp Control Module)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RCM(Restraint Control Module)																																																			
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	TCM(Transmission Control Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SYSTEM SEARCH																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ACM(Audio Control Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	CDP(Compact Disc Player)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EPS(Electronic Power Steering)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GDM(Generic Display Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GEM(Generic Electronic Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	IC(Instrument Cluster)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	NAV(Navigation System)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PAM(Parking Aid Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PDM(Passenger's Door Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RL_DCU(Rear Left Door Control Unit)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RR_DCU(Rear Right Door Control Unit)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SRM(Speech Recognition Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	HCM(Headlamp Control Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RCM(Restraint Control Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	SYSTEM SEARCH																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PCM(Powertrain Control Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ACM(Audio Control Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	D_DCU(Driver Door Control Unit)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EPS(Electronic power steering)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	GEM(Generic Electronic Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	HCM(Headlamp Control Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	IC(Instrument Cluster)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PAM(Parking Aid Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PDM(Passenger's Door Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RCM(Restraint Control Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RKE(Remote Keyless Entry)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TBM(Tracking and Blocking Module)																																																			
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TCM(Transmission Control Module)								V																																											
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PATS(Passive Anti Theft System)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	SYSTEM SEARCH																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CDP(Compact Disc Player)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CMR(Camera Module Rear)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	D_DCU(Driver Door Control Unit)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EPS(Electronic Power Steering)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FACM(Fuel Additive Control Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	GEM(Generic Electronic Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	HCM(Headlamp Control Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	IC(Instrument Cluster)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PDM(Passenger's Door Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PAM(Parking Aid Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RCM(Restraint Control Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RETM(Rear Entertainment Module)																																																			
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RKE(Remote Keyless Entry)																																																			
BETA-TEST	FUSION GASOLINE1.4L	SYSTEM SEARCH																																																			
BETA-TEST	FUSION GASOLINE1.4L	PCM(Powertrain Control Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FUSION GASOLINE1.4L	ACM(Audio Control Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	APIM(Accessory Protocol Interface Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	BCMii(Body Control Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	DDM(Driver's Door Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	FDSM(Front Distance Sensing Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	FCDIM(Front Control/Display Interface Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	GPSM(Global Positioning System Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	GWM(Gateway Module A)																																																			
BETA-TEST	FUSION GASOLINE1.4L	HVAC(Heating Ventilation Air Conditioning)																																																			
BETA-TEST	FUSION GASOLINE1.4L	IPC(Instrument Panel Control Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	PDM(Passenger's Door Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	PSCM(Power Steering Control Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	RCM(Restraint Control Module)																																																			
BETA-TEST	FUSION GASOLINE1.4L	RFA(Remote Function Actuator)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SYSTEM SEARCH																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	TCM(Transmission Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IC(Instrument Cluster)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	GEM(Generic Electronic Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ACM(Audio Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	BCMii(Body Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	FCDIM(Front Control/Display Interface Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IPC(Instrument Panel Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PSCM(Power Steering Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RCM(Retraint Control Module)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RFA(Remote Function Actuator)																																																			
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SRM(Speech Recognition Module)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SYSTEM SEARCH																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	TCM(Transmission Control Module)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	IC(Instrument Cluster)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ACM(Audio Control Module)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)																																																			
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)																																																			
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																																			
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																																																			
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	SYSTEM SEARCH																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	TCM(Transmission Control Module)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	IC(Instrument Cluster)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	ACM(Audio Control Module)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	GEM(Generic Electronic Module)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	SRM(Speech Recognition Module)																																																			
BETA-TEST	FIESTA 1.6L DURATEC 16V	PATS(Passive Anti Theft System)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SYSTEM SEARCH																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PCM(PowerTrain Control Module)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ACM(Audio Control Module)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	GEM(Generic Electronic Module)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	IC(Instrument Cluster)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SRM(Speech Recognition Module)																																																			
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PATS(Passive Anti Theft System)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	SYSTEM SEARCH																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PCM(PowerTrain Control Module)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	IC(Instrument Cluster)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RCM(Restraint Control Module)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RKE(Remote Keyless Entry)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	TCM(Transmission Control Module)																																																			
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PATS(Passive Anti Theft System)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	SYSTEM SEARCH																																																			
BETA-TEST	MONDEO-2.0L DIESEL	PCM(PowerTrain Control Module)																																						V	V												

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
BETA-TEST	MONDEO-2.0L DIESEL	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	BCMii(Body Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	CCMii(Cruise Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	CMR(Camera Module Rear)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	DDM(Driver's Door Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	DSM(Driver's Seat Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	HCM(Headlamp Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	IPC(Instrument Panel Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	PAM(Parking Aid Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	PBM(Parking Brake Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	PDM(Passenger's Door Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	PSCM(Power Steering Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	RCM(Restraint Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	RFA(Remote Function Actuator)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	SRM(Speech Recognition Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	TCM(Transmission Control Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	TRM(Trailer Module)																																																			
BETA-TEST	MONDEO-2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	SYSTEM SEARCH																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	PCM(PowerTrain Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	BCMii(Body Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	CCMii(Cruise Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	CMR(Camera Module Rear)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	DDM(Driver's Door Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	DSM(Driver's Seat Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	HCM(Headlamp Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	PAM(Parking Aid Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	PBM(Parking Brake Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	PDM(Passenger's Door Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	PSCM(Power Steering Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	RCM(Restraint Control Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	RFA(Remote Function Actuator)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	SRM(Speech Recognition Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	TCM(Transmission Control Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	PDC Reset	Infotainment Display Test	Audio Speaker Walkaround Test	DCSM Module Installation-Test	FDIM Module Installation	TR Sensor Test	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Transmitter	Erase All Remote Transmitter	ActuationTest	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	DPF Manual Regeneration	LIN New Module Initialization	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	Steering Wheel Position Sensor Calibration	Reset KAM(Keep Alive Memory)	Reset Differential Pressure Sensor Learned Values	Reset the Knock Sensor Learned Values	Fuel System Vaporizer Prime	Reset the front NOX Sensor Learned Values	Reset the rear NOX Sensor Learned Values	Reset the High Pressure Fuel Pump Learned Values	Active Torque Coupling Barcode Entry	EIPB Apply and Release Test	EIPB Maintenance Mode	Inlet Valve Calibration	Isolation Valve Calibration	RVC Configuration	LDWS Camera Alignment
BETA-TEST	MONDEO-2.5L GASOLINE	TRM(Trailer Module)																																																			
BETA-TEST	MONDEO-2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	SYSTEM SEARCH																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	PCM(PowerTrain Control Module)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	ACM(Audio Control Module)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	CDP(Compact Disc Player)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	GDM(Generic Display Module)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	GEM(Generic Electronic Module)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	NAV(Navigation System)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	RCM(Restraint Control Module)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	RETM(Rear Entertainment Module)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																																																			
BETA-TEST	MONDEO-3.0L Duratec-ST	SRM(Speech Recognition Module)																																																			
BETA-TEST	F-150 5.4L	SYSTEM SEARCH																																																			
BETA-TEST	F-150 5.4L	PCM(PowerTrain Control Module)								V																																											
BETA-TEST	F-150 5.4L	4X4(4x4 Control Module)																																																			
BETA-TEST	F-150 5.4L	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	F-150 5.4L	DSM(Driver Seat Module)																																																			
BETA-TEST	F-150 5.4L	EATC(Electronic Automatic Temperature Control)																																																			
BETA-TEST	F-150 5.4L	IC(Instrument Cluster)																																																			
BETA-TEST	F-150 5.4L	PAM(Parking Aid Module)																																																			
BETA-TEST	F-150 5.4L	RCM(Restraint Control Module)																																																			
BETA-TEST	F-150 5.4L	VSM(Vehicle Security Module)																																																			
BETA-TEST	F-150 5.4L	PATS(Passive Anti Theft System)																																																			
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	SYSTEM SEARCH																																																			
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PCM(PowerTrain Control Module)																																																			
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	ABS(Anti-Lock Brake System)																																																			
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	IC(Instrument Cluster)																																																			
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PAM(Parking Aid Module)																																																			
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	RCM(Restraint Control Module)																																																			
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	VSM(Vehicle Security Module)																																																			
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																			
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																			
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
Incode Calculator	~2010.05	All model																																																	
ESCAPE	Up to 2004	SYSTEM SEARCH																																																	
ESCAPE	Up to 2004	PCM(PowerTrain Control Module)																																																	
ESCAPE	Up to 2004	Immobilizer																																																	
ESCAPE	Up to 2004	ABS(Anti-Lock Brake System)																																																	
ESCAPE	Up to 2004	RCM(Restraint Control Module)																																																	
ESCAPE	Up to 2004	GEM(Generic Electronic Module)																																																	
ESCAPE	From 2004	SYSTEM SEARCH																																																	
ESCAPE	From 2004	PCM(PowerTrain Control Module)																																																	
ESCAPE	From 2004	PATS(Passive anti theft system)																																																	
ESCAPE	From 2004	ABS(Anti-Lock Brake System)																																																	
ESCAPE	From 2004	ABS(Anti-Lock Brake System)																																																	
ESCAPE	From 2004	RCM(Restraint Control Module)																																																	
ESCAPE	From 2004	IC(Instrument Cluster)																																																	
ESCAPE	From 2004	GEM(Generic Electronic Module)																																																	
EXPLORER	2011 MY	3.5L TiCVT	SYSTEM SEARCH																																																
EXPLORER	2011 MY	3.5L TiCVT	PCM(Powertrain Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	ABS(Anti-Lock Brake System)																																																
EXPLORER	2011 MY	3.5L TiCVT	ACM(Audio Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	APIM(Accessory Protocol Interface Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	BCM(Body Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	ATCM(All Terrain Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	C-CM(Cruise Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	CLM(Column Lock Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	DCSM(Driver-Dual Climate Contol Seat Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	DSM(Driver Seat Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	DSP(Digital Signal Processing Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	FCIM(Front Controls Interface Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	FCDIM(Front Control/Display Interface Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	FLM(Front Lighting Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	GPSM(Global Positioning System Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	HUD(Head Up Display)																																																
EXPLORER	2011 MY	3.5L TiCVT	HVAC(Heating Ventilation Air Conditioning)																																																
EXPLORER	2011 MY	3.5L TiCVT	IPC(Instrument Panel Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	LTM(Liftgate/Trunk Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	OCSM(Occupant Classification System Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	PAM(Parking Aid Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	PSCM(Power Steering Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	RCM(Restraint Control Module)																																																
EXPLORER	2011 MY	3.5L TiCVT	RFA(Remote Function Actuator)																																																
EXPLORER	2011 MY	3.5L TiCVT	RLCM-A(Rear Lighting Control Module A)																																																
EXPLORER	2011 MY	3.5L TiCVT	SCCM(Streering Colume Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
EXPLORER	2011 MY	3.5L TiCVT	SOD-L(Side Obstacle Detection Control Module Left)																																																	
EXPLORER	2011 MY	3.5L TiCVT	SOD-R(Side Obstacle Detection Control Module Right)																																																	
EXPLORER	2011 MY	3.5L TiCVT	TPM(Tire Pressure Monitor)																																																	
EXPLORER	2010 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2010 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2010 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER	2010 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2010 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER	2010 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER	2010 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2010 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER	2010 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER	2010 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2009 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2009 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2009 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER	2009 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2009 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER	2009 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER	2009 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2009 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER	2009 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER	2009 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2008 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2008 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2008 MY	4.6L	TCM(Transmission Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMli
EXPLORER	2008 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER	2008 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2008 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER	2008 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER	2008 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER	2008 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER	2008 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2008 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER	2008 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER	2008 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2008 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2007 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2007 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2007 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER	2007 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER	2007 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2007 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER	2007 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER	2007 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER	2007 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER	2007 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2007 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER	2007 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER	2007 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2007 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2006 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER	2006 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER	2006 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER	2006 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER	2006 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER	2006 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER	2006 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER	2006 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER	2006 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER	2006 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER	2006 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER	2006 MY	4.6L	PRB(Power Running Board)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
EXPLORER	2006 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER	2006 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER	2000 MY	SYSTEM SEARCH																																																		
EXPLORER	2000 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	2000 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	2000 MY	RCM(Restraint Control Module)																																																		
EXPLORER	2000 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER	2000 MY	GEM(Generic Electronic Module)																																																		
EXPLORER	2000 MY	PAM(Parking Aid Module)																																																		
EXPLORER	1999 MY	SYSTEM SEARCH																																																		
EXPLORER	1999 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	1999 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	1999 MY	RCM(Restraint Control Module)																																																		
EXPLORER	1999 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER	1999 MY	PAM(Parking Aid Module)																																																		
EXPLORER	1998 MY	SYSTEM SEARCH																																																		
EXPLORER	1998 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	1998 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	1998 MY	RCM(Restraint Control Module)																																																		
EXPLORER	1998 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER	1997 MY	SYSTEM SEARCH																																																		
EXPLORER	1997 MY	PCM(PowerTrain Control Module)																																																		
EXPLORER	1997 MY	ABS(Anti-Lock Brake System)																																																		
EXPLORER	1997 MY	RCM(Restraint Control Module)																																																		
EXPLORER	1997 MY	RIM(Remote Immobilizer Module)																																																		
EXPLORER SPORT-TRAC	2010 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	RCM(Restraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMli
EXPLORER SPORT-TRAC	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
EXPLORER SPORT-TRAC	2007 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	SYSTEM SEARCH																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	PCM(Powertrain Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	TCM(Transmission Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	4X4(4x4 Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	ACM(Audio Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	DSM(Driver's Seat Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	GEM(Generic Electronic Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	IC(Instrument Cluster)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	PAM(Parking Aid Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	PRB(Power Running Board)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	RCM(Restraint Control Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	RETM(Rear Entertainment Module)																																																	
EXPLORER SPORT-TRAC	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	BCM(Body Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	GPSM(Global Positioning System Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
ECOSPORT	1.5L	DURATEC VCT	SYSTEM SEARCH																																																	
ECOSPORT	1.5L	DURATEC VCT	PCM(Powertrain Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	ABS(Anti-Lock Brake System)																																																	
ECOSPORT	1.5L	DURATEC VCT	ACM(Audio Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	BCMii(Body Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	GPSM(Global Positioning System Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																	
ECOSPORT	1.5L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	PSCM(Power Steering Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	RCM(Restraint Control Module)																																																	
ECOSPORT	1.5L	DURATEC VCT	RFA(Remote Function Actuator)																																																	
ECOSPORT	1.5L	DURATEC VCT	TCM(Transmission Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	SYSTEM SEARCH																																																	
FIESTA	1.25L	DURATEC 16V	PCM(PowerTrain Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.25L	DURATEC 16V	ACM(Audio Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	APIM(Accessory Protocol Interface Module)																																																	
FIESTA	1.25L	DURATEC 16V	BCMii(Body Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	DDM(Driver's Door Module)																																																	
FIESTA	1.25L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.25L	DURATEC 16V	FDSM(Front Distance Sensing Module)																																																	
FIESTA	1.25L	DURATEC 16V	GPSM(Global Positioning System Module)																																																	
FIESTA	1.25L	DURATEC 16V	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.25L	DURATEC 16V	IPC(Instrument Panel Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	PDM(Passenger's Door Module)																																																	
FIESTA	1.25L	DURATEC 16V	PSCM(Power Steering Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	RCM(Restraint Control Module)																																																	
FIESTA	1.25L	DURATEC 16V	RFA(Remote Function Actuator)																																																	
FIESTA	1.4L GASOLINE	SYSTEM SEARCH																																																		
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The Installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)																																																		
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)																																																		
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.4L GASOLINE	APIM(Accessory Protocol Interface Module)																																																		
FIESTA	1.4L GASOLINE	PSCM(Power Steering Control Module)																																																		
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)																																																		
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)																																																		
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.4L GASOLINE	GEM(Generic Electronic Module)																																																		
FIESTA	1.4L GASOLINE	BCMii(Body Control Module)																																																		
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
FIESTA	1.4L GASOLINE	RFA(Remote Function Actuator)																																																		
FIESTA	1.4L GASOLINE	SRM(Speech Recognition Module)																																																		
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)																																																		
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)																																																		
FIESTA	1.4L GASOLINE	DDM(Driver's Door Module)																																																		
FIESTA	1.4L GASOLINE	FDSM(Front Distance Sensing Module)																																																		
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.4L GASOLINE	GPSM(Global Positioning System Module)																																																		
FIESTA	1.4L GASOLINE	PDM(Passenger's Door Module)																																																		
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																
FIESTA	1.5L	TiVCT	SYSTEM SEARCH																																																
FIESTA	1.5L	TiVCT	PCM(PowerTrain Control Module)																																																
FIESTA	1.5L	TiVCT	ABS(Anti-Lock Brake System)																																																
FIESTA	1.5L	TiVCT	ACM(Audio Control Module)																																																
FIESTA	1.5L	TiVCT	BCMii(Body Control Module)																																																
FIESTA	1.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																																																
FIESTA	1.5L	TiVCT	IPC(Instrument Panel Control Module)																																																
FIESTA	1.5L	TiVCT	PSCM(Power Steering Control Module)																																																
FIESTA	1.5L	TiVCT	RCM(Retraint Control Module)																																																
FIESTA	1.5L	TiVCT	RFA(Remote Function Actuator)																																																
FIESTA	1.5L	TiVCT	SRM(Speech Recognition Module)																																																
FIESTA	1.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																																																
FIESTA	1.5L	TiVCT	TCM(Transmission Control Module)																																																
FIESTA	1.6L GASOLINE	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)																																																		
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)																																																		
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.6L GASOLINE	PSCM(Power Steering Control Module)																																																		
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)																																																		
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)																																																		
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																																		
FIESTA	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)																																																		
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)																																																		
FIESTA	1.6L GASOLINE	BCMii(Body Control Module)																																																		
FIESTA	1.6L GASOLINE	FCDIM(Front Control/Display Interface Module)																																																		
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)																																																		
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)																																																		
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)																																																		
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)																																																		
FIESTA	1.6L ZETEC ROCAM	SYSTEM SEARCH																																																		
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)																																																		
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)																																																		
FIESTA	1.6L ZETEC ROCAM	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.6L ZETEC ROCAM	IC(Instrument Cluster)																																																		
FIESTA	1.6L ZETEC ROCAM	RCM(Restraint Control Module)																																																		
FIESTA	1.6L ZETEC ROCAM	RKE(Remote Keyless Entry)																																																		
FIESTA	1.6L ZETEC ROCAM	TCM(Transmission Control Module)																																																		
FIESTA	1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																																		
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																		
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																		
FIESTA	1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																																																		
FIESTA	1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																																																		
FIESTA	1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																																																		
FIESTA	2.0L GASOLINE	SYSTEM SEARCH																																																		
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																		
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																	
FIESTA	2.0L GASOLINE	ACM(Audio Control Module)																																																	
FIESTA	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
FIESTA	2.0L GASOLINE	GEM(Generic Electronic Module)																																																	
FIESTA	2.0L GASOLINE	IC(Instrument Cluster)																																																	
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)																																																	
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)																																																	
FIESTA	2.0L GASOLINE	RCM(Restraint Control Module)																																																	
FIESTA	2.0L GASOLINE	PATS(Passive Anti Theft System)-BETA																																																	
FIGO	1.4L DIESEL	SYSTEM SEARCH																																																	
FIGO	1.4L DIESEL	PCM(Powertrain Control Module)																																																	
FIGO	1.4L DIESEL	ABS(Anti-Lock Brake System)																																																	
FIGO	1.4L DIESEL	IC(Instrument Cluster)																																																	
FIGO	1.4L DIESEL	RCM(Restraint Control Module)																																																	
FIGO	1.6L	DURATEC 16V	SYSTEM SEARCH																																																
FIGO	1.6L	DURATEC 16V	PCM(Powertrain Control Module)																																																
FIGO	1.6L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																
FIGO	1.6L	DURATEC 16V	GEM(Generic Electronic Module)																																																
FIGO	1.6L	DURATEC 16V	IC(Instrument Cluster)																																																
FIGO	1.6L	DURATEC 16V	RCM(Restraint Control Module)																																																
FIGO	1.6L	DURATEC 16V	TCM(Transmission Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM(Front Distance Sensing Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																	
FOCUS	1.4L	DURATEC 16V	SYSTEM SEARCH																																																	
FOCUS	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.4L	DURATEC 16V	ACM(Audio Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	CDP(Compact Disc Player)																																																	
FOCUS	1.4L	DURATEC 16V	D_DCU(Driver Door Control Unit)																																																	
FOCUS	1.4L	DURATEC 16V	GDM(Generic Display Module)																																																	
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																																																	
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																																																	
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	1.4L	DURATEC 16V	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS	1.4L	DURATEC 16V	IC(Instrument Cluster)																																																	
FOCUS	1.4L	DURATEC 16V	NAV(Navigation System)																																																	
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)																																																	
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)																																																	
FOCUS	1.4L	DURATEC 16V	PDM(Passenger's Door Module)																																																	
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)																																																	
FOCUS	1.4L	DURATEC 16V	RKE(Remote Keyless Entry)																																																	
FOCUS	1.4L	DURATEC 16V	CSM(Central Security Module)																																																	
FOCUS	1.4L	DURATEC 16V	HEC(Hybrid Electrical Cluster)																																																	
FOCUS	1.4L	DURATEC 16V	MC(Message Center)																																																	
FOCUS	1.4L	DURATEC 16V	RETM(Rear Entertainment Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TCM(Transmission Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body control module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	CCMii(Cruise Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DDM(Driver's Door Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DDM(Driver's Door Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCIM(Front Controls Interface Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FDSM(Front Distance Sensing Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GPSM(Global Positioning System Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HCM(Headlamp Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HVAC(Heating Ventilation Air Conditioning)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPC(Instrument Panel Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PAM(Parking Aid Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PDM(Passenger's Door Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PSCM(Power Steering Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RCM(Restraint Control Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RFA(Remote Function Actuator)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SASM(Steering Angle Sensor Module)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TRM(Trailer Module)																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	SYSTEM SEARCH																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	PCM(PowerTrain Control Module)																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	GEM(Generic Electronic Module)																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	RCM(Restraint Control Module)																																																	
FOCUS	1.6L GASOLINE	ZETEC SE	MC(Message Center)																																																	
FOCUS	1.6L GASOLINE	DURATEC	SYSTEM SEARCH																																																	
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L GASOLINE	DURATEC	ACM(Audio Control Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	CDP(Compact Disc Player)																																																	
FOCUS	1.6L GASOLINE	DURATEC	D_DCU(Driver Door Control Unit)																																																	
FOCUS	1.6L GASOLINE	DURATEC	GDM(Generic Display Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	1.6L GASOLINE	DURATEC	FFH(Fuel Fired Coolant Heating Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
FOCUS	1.6L GASOLINE	DURATEC	IC(Instrument Cluster)																																																	
FOCUS	1.6L GASOLINE	DURATEC	NAV(Navigation System)																																																	
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	PDM(Passenger's Door Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	RKE(Remote Keyless Entry)																																																	
FOCUS	1.6L GASOLINE	DURATEC	RL_DCU(Rear Left Door Control Unit)																																																	
FOCUS	1.6L GASOLINE	DURATEC	RR_DCU(Rear Right Door Control Unit)																																																	
FOCUS	1.6L GASOLINE	DURATEC	CSM(Central Security Module)																																																	
FOCUS	1.6L GASOLINE	DURATEC	HEC(Hybrid Electrical Cluster)																																																	
FOCUS	1.6L GASOLINE	DURATEC	MC(Message Center)																																																	
FOCUS	1.6L GASOLINE	DURATEC	PATS(Passive Anti Theft System)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SYSTEM SEARCH																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TCM(Transmission Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	APIM(Accessory Protocol Interface Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	BCMii(Body Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	CCMii(Cruise Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DDM(Driver's Door Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DSP(Digital Signal Processing Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCIM(Front Controls Interface Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FDSM(Front Distance Sensing Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HCM(Headlamp Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-A(Image Processing Module A)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-B(Image Processing Module B)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPC(Instrument Panel Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PSCM(Power Steering Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RFA(Remote Function Actuator)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SASM(Steering Angle Sensor Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SRM(Speech Recognition Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TRM(Trailer Module)																																																	
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PATS(Passive Anti Theft System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GDM(Generic Display Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	NAV(Navigation System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Condtioning)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Condtioning)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CMR(Camera Module Rear)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CDP(Compact Disc Player)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPB(Electronic Parking Brake)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPS(Electronic Power Steering)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GDM(Generic Display Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HCM(Headlamp Control Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	IC(Instrument Cluster)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	NAV(Navigation System)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PDM(Passenger's Door Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CSM(Central Security Module)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	MC(Message Center)																																																	
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SYSTEM SEARCH																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	TCM(Transmission Control Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ACM(Audio Control Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CMR(Camera Module Rear)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CDP(Compact Disc Player)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CSM(Central Security Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPB(Electronic Parking Brake)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPS(Electronic Power Steering)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GDM(Generic Display Module)																																																	
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HCM(Headlamp Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	IC(Instrument Cluster)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	NAV(Navigation System)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PAM(Parking Aid Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PDM(Passenger's Door Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SRM(Speech Recognition Module)																																																
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SYSTEM SEARCH																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TCM(Transmission Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	APIM(Accessory Protocol Interface Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	BCMii(Body Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	CCMii(Cruise Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DDM(Driver's Door Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DSP(Digital Signal Processing Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCIM(Front Controls Interface Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FDSM(Front Distance Sensing Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCDIM(Front Control/Display Interface Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HCM(Headlamp Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-A(Image Processing Module A)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-B(Image Processing Module B)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPC(Instrument Panel Control Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)																																																
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PSCM(Power Steering Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RFA(Remote Function Actuator)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SASM(Steering Angle Sensor Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SRM(Speech Recognition Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TRM(Trailer Module)																																																	
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PATS(Passive Anti Theft System)																																																	
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	SYSTEM SEARCH																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PCM(PowerTrain Control Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	TCM(Transmission Control Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ACM(Audio Control Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ABS(Anti-Lock Brake System)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CDP(Compact Disc Player)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CMR(Camera Module Rear)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	D_DCU(Driver Door Control Unit)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	EATC(Electronic Automatic Temperature Control)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	EPS(Electronic Power Steering)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FACM(Fuel Additive Control Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FFH(Fuel Fired Coolant Heating Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	GEM(Generic Electronic Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	HCM(Headlamp Control Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	IC(Instrument Cluster)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PDM(Passenger's Door Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PAM(Parking Aid Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RCM(Restraint Control Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RETM(Rear Entertainment Module)																																																
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RKE(Remote Keyless Entry)																																																
FOCUS	2.5L GASOLINE	SYSTEM SEARCH																																																		
FOCUS	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																		
FOCUS	2.5L GASOLINE	TCM(Transmission Control Module)																																																		
FOCUS	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FOCUS	2.5L GASOLINE	EPS(Electronic Power Steering)																																																		
FOCUS	2.5L GASOLINE	RCM(Restraint Control Module)																																																		
FOCUS	2.5L GASOLINE	GEM(Generic Electronic Module)																																																		
FOCUS	2.5L GASOLINE	IC(Instrument Cluster)																																																		
FOCUS	2.5L GASOLINE	DDM(Driver's Door Module)																																																		
FOCUS	2.5L GASOLINE	PDM(Passenger's Door Module)																																																		
FOCUS	2.5L GASOLINE	MC(Message Center)																																																		
FOCUS	2.5L GASOLINE	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
FOCUS C-MAX	1.6L DIESEL	SYSTEM SEARCH																																																	
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																	
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																	
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	CDP(Compact Disc Player)																																																	
FOCUS C-MAX	1.6L DIESEL	CMR(Camera Module Rear)																																																	
FOCUS C-MAX	1.6L DIESEL	D_DCU(Driver Door Control Unit)																																																	
FOCUS C-MAX	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
FOCUS C-MAX	1.6L DIESEL	EPS(Electronic Power Steering)																																																	
FOCUS C-MAX	1.6L DIESEL	FACM(Fuel Additive Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
FOCUS C-MAX	1.6L DIESEL	GEM(Generic Electronic Module)																																																	
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	IC(Instrument Cluster)																																																	
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)																																																	
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)																																																	
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)																																																	
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)																																																	
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	RETM(Rear Entertainment Module)																																																	
FOCUS C-MAX	1.6L DIESEL	RKE(Remote Keyless Entry)																																																	
FOCUS C-MAX	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	BCMii(Body Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	DDM(Driver's Door Module)																																																	
FOCUS C-MAX	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)																																																	
FOCUS C-MAX	1.6L DIESEL	HVAC(Heating Ventilation Air Condtioning)																																																	
FOCUS C-MAX	1.6L DIESEL	IPM-A(Image Processing Module A)																																																	
FOCUS C-MAX	1.6L DIESEL	IPM-B(Image Processing Module B)																																																	
FOCUS C-MAX	1.6L DIESEL	IPC(Instrument Panel Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	PSCM(Power Steering Control Module)																																																	
FOCUS C-MAX	1.6L DIESEL	RFA(Remote Function Actuator)																																																	
FOCUS C-MAX	1.6L DIESEL	RGTM(Rear Gate/Trunk Module)																																																	
FOCUS C-MAX	1.6L DIESEL	SASM(Steering Angle Sensor Module)																																																	
FOCUS C-MAX	1.6L DIESEL	SRM(Speech Recognition Module)																																																	
FOCUS C-MAX	1.6L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																	
FOCUS C-MAX	1.6L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																	
FOCUS C-MAX	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
FOCUS C-MAX	1.6L GASOLINE	SYSTEM SEARCH																																																		
FOCUS C-MAX	1.6L GASOLINE	PCM(PowerTrain Control Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FOCUS C-MAX	1.6L GASOLINE	ACM(Audio Control Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	CDP(Compact Disc Player)																																																		
FOCUS C-MAX	1.6L GASOLINE	CMR(Camera Module Rear)																																																		
FOCUS C-MAX	1.6L GASOLINE	D_DCU(Driver Door Control Unit)																																																		
FOCUS C-MAX	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS C-MAX	1.6L GASOLINE	EPS(Electronic Power Steering)																																																		
FOCUS C-MAX	1.6L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	GEM(Generic Electronic Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	IC(Instrument Cluster)																																																		
FOCUS C-MAX	1.6L GASOLINE	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	PDM(Passenger's Door Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	RETM(Rear Entertainment Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	RKE(Remote Keyless Entry)																																																		
FOCUS C-MAX	1.6L GASOLINE	GDM(Generic Display Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	NAV(Navigation System)																																																		
FOCUS C-MAX	1.6L GASOLINE	RL_DCU(Rear Left Door Control Unit)																																																		
FOCUS C-MAX	1.6L GASOLINE	RR_DCU(Rear Right Door Control Unit)																																																		
FOCUS C-MAX	1.6L GASOLINE	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	1.6L GASOLINE	TCM(Transmission Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	SYSTEM SEARCH																																																		
FOCUS C-MAX	1.8L GASOLINE	PCM(PowerTrain Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FOCUS C-MAX	1.8L GASOLINE	ACM(Audio Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	CMR(Camera Module Rear)																																																		
FOCUS C-MAX	1.8L GASOLINE	CDP(Compact Disc Player)																																																		
FOCUS C-MAX	1.8L GASOLINE	D_DCU(Driver Door Control Unit)																																																		
FOCUS C-MAX	1.8L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS C-MAX	1.8L GASOLINE	EPB(Electronic Parking Brake)																																																		
FOCUS C-MAX	1.8L GASOLINE	EPS(Electronic Power Steering)																																																		
FOCUS C-MAX	1.8L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	GDM(Generic Display Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	GEM(Generic Electronic Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	IC(Instrument Cluster)																																																		
FOCUS C-MAX	1.8L GASOLINE	NAV(Navigation System)																																																		
FOCUS C-MAX	1.8L GASOLINE	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	PDM(Passenger's Door Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
FOCUS C-MAX	1.8L GASOLINE	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	RETM(Rear Entertainment Module)																																																		
FOCUS C-MAX	1.8L GASOLINE	RKE(Remote Keyless Entry)																																																		
FOCUS C-MAX	1.8L GASOLINE	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SYSTEM SEARCH																																																		
FOCUS C-MAX	2.0L DIESEL	PCM(PowerTrain Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																		
FOCUS C-MAX	2.0L DIESEL	ACM(Audio Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	BCMii(Body Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	DDM(Driver's Door Module)																																																		
FOCUS C-MAX	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																																																		
FOCUS C-MAX	2.0L DIESEL	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
FOCUS C-MAX	2.0L DIESEL	IPM-A(Image Processing Module A)																																																		
FOCUS C-MAX	2.0L DIESEL	IPM-B(Image Processing Module B)																																																		
FOCUS C-MAX	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	2.0L DIESEL	PDM(Passenger's Door Module)																																																		
FOCUS C-MAX	2.0L DIESEL	PSCM(Power Steering Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	2.0L DIESEL	RFA(Remote Function Actuator)																																																		
FOCUS C-MAX	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SRM(Speech Recognition Module)																																																		
FOCUS C-MAX	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																		
FOCUS C-MAX	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																		
FOCUS C-MAX	2.0L GASOLINE	SYSTEM SEARCH																																																		
FOCUS C-MAX	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																		
FOCUS C-MAX	2.0L GASOLINE	ACM(Audio Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	CDP(Compact Disc Player)																																																		
FOCUS C-MAX	2.0L GASOLINE	CMR(Camera Module Rear)																																																		
FOCUS C-MAX	2.0L GASOLINE	D_DCU(Driver Door Control Unit)																																																		
FOCUS C-MAX	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																		
FOCUS C-MAX	2.0L GASOLINE	EPB(Electronic Parking Brake)																																																		
FOCUS C-MAX	2.0L GASOLINE	EPS(Electronic Power Steering)																																																		
FOCUS C-MAX	2.0L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	GDM(Generic Display Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	GEM(Generic Electronic Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	HCM(Headlamp Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	IC(Instrument Cluster)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
FOCUS C-MAX	2.0L GASOLINE	NAV(Navigation System)																																																		
FOCUS C-MAX	2.0L GASOLINE	PAM(Parking Aid Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	PDM(Passenger's Door Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	RCM(Restraint Control Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	RETM(Rear Entertainment Module)																																																		
FOCUS C-MAX	2.0L GASOLINE	RKE(Remote Keyless Entry)																																																		
FOCUS C-MAX	2.0L GASOLINE	SRM(Speech Recognition Module)																																																		
FUSION	1.4L DIESEL	SYSTEM SEARCH																																																		
FUSION	1.4L DIESEL	PCM(PowerTrain Control Module)																																																		
FUSION	1.4L DIESEL	TCM(Transmission Control Module)																																																		
FUSION	1.4L DIESEL	ABS(Anti-Lock Brake System)																																																		
FUSION	1.4L DIESEL	IC(Instrument Cluster)																																																		
FUSION	1.4L DIESEL	ACM(Audio Control Module)																																																		
FUSION	1.4L DIESEL	EATC(Electronic Automatic Temperature Control)																																																		
FUSION	1.4L DIESEL	GEM(Generic Electronic Module)																																																		
FUSION	1.4L DIESEL	SRM(Speech Recognition Module)																																																		
FUSION	1.4L DIESEL	RCM(Restraint Control Module)																																																		
FUSION	1.4L DIESEL	PATS(Passive Anti Theft System)-BETA																																																		
FUSION	1.6L DIESEL	SYSTEM SEARCH																																																		
FUSION	1.6L DIESEL	PCM(PowerTrain Control Module)																																																		
FUSION	1.6L DIESEL	TCM(Transmission Control Module)																																																		
FUSION	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																		
FUSION	1.6L DIESEL	IC(Instrument Cluster)																																																		
FUSION	1.6L DIESEL	ACM(Audio Control Module)																																																		
FUSION	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)																																																		
FUSION	1.6L DIESEL	GEM(Generic Electronic Module)																																																		
FUSION	1.6L DIESEL	SRM(Speech Recognition Module)																																																		
FUSION	1.6L DIESEL	RCM(Restraint Control Module)																																																		
FUSION	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																		
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																																	
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TCM(Transmission Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CDP(Compact Disc Player)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CMR(Camera Module Rear)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DABM(Digital Audio Broadcast Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver's Seat Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	NAV(Navigation System)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PBM(Parking Brake Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module - Left)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module - Right)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																	
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																																																	
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																																																	
F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																																																	
F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																																																	
F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																																																	
F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																																																	
F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																																																	
F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																																																	
F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																																																	
F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																																																	
F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																																																	
F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																																																	
F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																																																	
F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																																																	
F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																																																	
F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																																																	
F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																																																	
F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																																																	
F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																																																	
F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																																																	
F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																																																	
F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																																																	
F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																																																	
F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																																																	
F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																																																
F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																																																
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																																																
F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																																																
F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																																																
F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																																																
F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																																																
F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																																																
F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																																																
F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																																																
F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																																																
F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																																																
F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																																																
F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																																																
F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																																																
F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																																																
F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																																																
F150	4.6L(BETA)	3V	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																																																	
F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																																																	
F150	4.6L(BETA)	3V	ACM(Audio Control Module)																																																	
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																																																	
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																																																	
F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																																																	
F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																																																	
F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																																																	
F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																																																	
F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																																																	
F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																																																	
F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	4.6L(BETA)	3V	IC(Instrument Cluster)																																																	
F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																																																	
F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																																																	
F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																																																	
F150	4.6L(BETA)	3V	PRB(Power Running Board)																																																	
F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																																																	
F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																																																	
F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																																																	
F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																																																	
F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																																																	
F150	5.0L	TiVCT	SYSTEM SEARCH																																																	
F150	5.0L	TiVCT	PCM(Powertrain Control Module)																																																	
F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																																																	
F150	5.0L	TiVCT	ACM(Audio Control Module)																																																	
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																																																	
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																																																	
F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																																																	
F150	5.0L	TiVCT	DSM(Driver's Seat Module)																																																	
F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																																																	
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																																	
F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																																																	
F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																																																	
F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																																																	
F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	5.0L	TiVCT	IC(Instrument Cluster)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The Installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																																																	
F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																																																	
F150	5.0L	TiVCT	PAM(Parking Aid Module)																																																	
F150	5.0L	TiVCT	PAM(Parking Aid Module)																																																	
F150	5.0L	TiVCT	PRB(Power Running Board)																																																	
F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																																																	
F150	5.0L	TiVCT	RCM(Restraint Control Module)																																																	
F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																																																	
F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																																																	
F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																																																	
F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																																																	
F150	5.0L	TiVCT	TCM(Transmission Control Module)																																																	
F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																																																	
F150	5.4L	3V	2009 ~	SYSTEM SEARCH																																																
F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																																																
F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																																																
F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																																																
F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																																																
F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																																																
F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																																																
F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																																																
F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																																																
F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																																																
F150	5.4L	3V	2009 ~	GEMS/JB(Generic Electronic Module/Smart Junction Box)																																																
F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																																																
F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																																																
F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																																																
F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																																																
F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																																																
F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																																																
F150	5.4L	3V	2009 ~	PRB(Power Running Board)																																																
F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																																																
F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																																																
F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																																																
F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																																																
F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																																																
F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																																																
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																																																
F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																																																
F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																																																
F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																																																
F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																																
F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																																																
F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																																																
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																																																
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																																																
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																																																
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																																																
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																																																
F150	6.2L(BETA)	2V	SYSTEM SEARCH																																																	
F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																																																	
F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																																																	
F150	6.2L(BETA)	2V	ACM(Audio Control Module)																																																	
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																																																	
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																																																	
F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																																																	
F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																																																	
F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																																																	
F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																																																	
F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																																																	
F150	6.2L(BETA)	2V	IC(Instrument Cluster)																																																	
F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																																																	
F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																																																	
F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																																																	
F150	6.2L(BETA)	2V	PRB(Power Running Board)																																																	
F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																																																	
F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																																																	
F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																																																	
F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																																																	
F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																																																	
F150	Other	2004 ~ 2008	SYSTEM SEARCH																																																	
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																																																	
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																																																	
F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																																																	
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																	
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																																																	
F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																																																	
F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																																																	
F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																																	
F150	Other	2004 ~ 2008	IC(Instrument Cluster)																																																	
F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																																																	
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																																																	
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																																																	
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																																																	
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																																																	
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																																																	
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																																																	
F250	7.3L	SYSTEM SEARCH																																																		
F250	7.3L	PCM(PowerTrain Control Module)																																																		
F250	7.3L	ABS(Anti-Lock Brake System)																																																		
F250	7.3L	ECS(Electronic Crash Sensor)																																																		
F250	7.3L	GEM(Generic Electronic Module)																																																		
F250	6.2L	SYSTEM SEARCH																																																		
F250	6.2L	PCM(Powertrain Control Module)																																																		
F250	6.2L	ABS(Anti-Lock Brake System)																																																		
F250	6.2L	ACM(Audio Control Module)																																																		
F250	6.2L	APIM(Accessory Protocol Interface Module)																																																		
F250	6.2L	BCMii(Body Control Module)																																																		
F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																																																		
F250	6.2L	DSM(Driver Seat Module)																																																		
F250	6.2L	GPSM(Global Positioning System Module)																																																		
F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																																																		
F250	6.2L	IPC(Instrument Panel Control Module)																																																		
F250	6.2L	PAM(Parking Aid Module)																																																		
F250	6.2L	RCM(Restraint Control Module)																																																		
F250	6.2L	SCCM(Streering Colume Control Module)																																																		
F250	6.2L	TBC(Trailer Brake Control Module)																																																		
F250	6.2L	TCCM(Transfer Case Control Module)																																																		
F250	6.2L	TPM(Tire Pressure Monitor)																																																		
F250	6.0L Diesel	SYSTEM SEARCH																																																		
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																		
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																		
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																																		
F250	6.0L Diesel	ABS(Anti-Lock Brake System)																																																		
F250	6.0L Diesel	GEM(Generic Electronic Module)																																																		
F250	6.0L Diesel	HEC(Hybrid Electrical Cluster)																																																		
F250	6.0L Diesel	OTC(Overhead Trip Computer)																																																		
F250	6.0L Diesel	PAM(Parking Aid Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
F250	6.0L Diesel	PATS(Passive Anti Theft System)																																																	
F250	6.0L Diesel	RCM(Restraint Control Module)																																																	
F250	6.0L Diesel	TCM(Transmission Control Module)																																																	
F250	6.0L Diesel	TCM(Transmission Control Module)																																																	
F250	6.0L Diesel	TCM(Transmission Control Module)																																																	
F250	6.0L Diesel	VSM(Vehicle Security Module)																																																	
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMli
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																																																
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																																																
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																	
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																																	
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																																	
KA	KA	SYSTEM SEARCH																																																		
KA	KA	PCM(PowerTrain Control Module)																																																		
KA	KA	ABS(Anti-Lock Brake System)																																																		
KA	KA	RCM(Restraint Control Module)																																																		
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																	
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																	
KUGA	2.0L DIESEL	SYSTEM SEARCH																																																		
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)																																																		
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)																																																		
KUGA	2.0L DIESEL	TCM(Transmission Control Module)																																																		
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																		
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																		
KUGA	2.0L DIESEL	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
KUGA	2.0L DIESEL	ACM(Audio Control Module)																																																	
KUGA	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
KUGA	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																																																	
KUGA	2.0L DIESEL	AWD(All Wheel Drive Module)																																																	
KUGA	2.0L DIESEL	BCMii(Body Control Module)																																																	
KUGA	2.0L DIESEL	CCMii(Cruise Control Module)																																																	
KUGA	2.0L DIESEL	CMR(Camera Module Rear)																																																	
KUGA	2.0L DIESEL	D_DCU(Driver Door Control Unit)																																																	
KUGA	2.0L DIESEL	DDM(Driver's Door Module)																																																	
KUGA	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
KUGA	2.0L DIESEL	EPS(Electronic Power Steering)																																																	
KUGA	2.0L DIESEL	FDSM(Front Distance Sensing Module)																																																	
KUGA	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																																																	
KUGA	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
KUGA	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
KUGA	2.0L DIESEL	GPSM(Global Positioning System Module)																																																	
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)																																																	
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)																																																	
KUGA	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
KUGA	2.0L DIESEL	IPM-A(Image Processing Module A)																																																	
KUGA	2.0L DIESEL	IPM-B(Image Processing Module B)																																																	
KUGA	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																	
KUGA	2.0L DIESEL	IC(Instrument Cluster)																																																	
KUGA	2.0L DIESEL	PAM(Parking Aid Module)																																																	
KUGA	2.0L DIESEL	PAM(Parking Aid Module)																																																	
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)																																																	
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)																																																	
KUGA	2.0L DIESEL	PSCM(Power Steering Control Module)																																																	
KUGA	2.0L DIESEL	RCM(Restraint Control Module)																																																	
KUGA	2.0L DIESEL	RCM(Restraint Control Module)																																																	
KUGA	2.0L DIESEL	RFA(Remote Function Actuator)																																																	
KUGA	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																	
KUGA	2.0L DIESEL	RETM(Rear Entertainment Module)																																																	
KUGA	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																	
KUGA	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																																	
KUGA	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																																	
KUGA	2.0L DIESEL	SRM(Speech Recognition Module)																																																	
KUGA	2.0L DIESEL	TRM(Trailer Module)																																																	
KUGA	2.5L GASOLINE	SYSTEM SEARCH																																																	
KUGA	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
KUGA	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
KUGA	2.5L GASOLINE	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
KUGA	2.5L GASOLINE	AWD(All Wheel Drive Module)																																																	
KUGA	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
KUGA	2.5L GASOLINE	D_DCU(Driver Door Control Unit)																																																	
KUGA	2.5L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
KUGA	2.5L GASOLINE	EPS(Electronic Power Steering)																																																	
KUGA	2.5L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																																	
KUGA	2.5L GASOLINE	GEM(Generic Electronic Module)																																																	
KUGA	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
KUGA	2.5L GASOLINE	IC(Instrument Cluster)																																																	
KUGA	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
KUGA	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
KUGA	2.5L GASOLINE	RCM(Restraint Control Module)																																																	
KUGA	2.5L GASOLINE	RETM(Rear Entertainment Module)																																																	
KUGA	2.5L GASOLINE	RKE(Remote Keyless Entry)																																																	
KUGA	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
KUGA	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The Installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	CCMii(Cruise Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DCDC(DC to DC Convertal Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DDM(Driver's Door Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSM(Driver Seat Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSP(Digital Signal Processing Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCIM(Front Controls Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FDSM(Front Distance Sensing Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCDIM(Front Control/Display Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GPSM(Global Positioning System Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GWM(Gateway Module A)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HCM(Headlamp Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HSWM(Heated Steering Wheel Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HUD(Head Up Display)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPC(Instrument Panel Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PAM(Parking Aid Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PDM(Passenger's Door Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PSCM(Power Steering Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RACM(Rear Audio Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RCM(Restraint Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RTM(Radio Transceiver Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCCM(Streering Colume Control Module)	V																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-E(Seat Control Module E)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-G(Seat Control Module G)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-H(Seat Control Module H)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SOD-L(Side Obstacle Detection Control Module Left)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SOD-R(Side Obstacle Detection Control Module Right)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TRM(Trailer Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DCDC(DC to DC Convertal Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver Seat Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSP(Digital Signal Processing Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GWM(Gateway Module A)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HSWM(Heated Steering Wheel Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HUD(Head Up Display)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RACM(Rear Audio Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RTM(Radio Transceiver Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCCM(Streering Colume Control Module)	V																																															
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-E(Seat Control Module E)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-G(Seat Control Module G)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-H(Seat Control Module H)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																																
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2012 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2012 MY	2.0L DIESEL	PCM(PowerTrain Control Module)			V																																														
MONDEO	2012 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2012 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	BCMii(Body Control Module)				V																																													
MONDEO	2012 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2012 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2012 MY	2.0L DIESEL	IPM-A(Image Processing Module A)																																																	
MONDEO	2012 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																	
MONDEO	2012 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
MONDEO	2012 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)					V																																												
MONDEO	2012 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)						V																																											
MONDEO	2012 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	TRM(Trailer Module)																																																	
MONDEO	2012 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																																
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																																
MONDEO	2011 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2011 MY	2.0L DIESEL	PCM(PowerTrain Control Module)			V																																														
MONDEO	2011 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2011 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	BCMii(Body Control Module)				V																																													
MONDEO	2011 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2011 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2011 MY	2.0L DIESEL	IPM-A(Image Processing Module A)																																																	
MONDEO	2011 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																	
MONDEO	2011 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)																																																	
MONDEO	2011 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)					V																																												
MONDEO	2011 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)						V																																											
MONDEO	2011 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	TRM(Trailer Module)																																																	
MONDEO	2011 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2011 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)							V																																										
MONDEO	2011 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2011 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2011 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2011 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)								V																																									
MONDEO	2011 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	RCM(Restraint Control Module)									V																																								
MONDEO	2011 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2011 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	TCM(Transmission Control Module)										V	V	V																																					
MONDEO	2011 MY	2.3L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																	
MONDEO	2011 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA													V																																				
MONDEO	2011 MY	2.5L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2011 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2011 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2011 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2011 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	RCM(Restraint Control Module)									V																																								
MONDEO	2011 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2011 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2011 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA													V																																				

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2010 MY	2.0L	DIESEL	SYSTEM SEARCH																																															
MONDEO	2010 MY	2.0L	DIESEL	PCM(PowerTrain Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	ABS(Anti-Lock Brake System)						V							V																																		
MONDEO	2010 MY	2.0L	DIESEL	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	BCMii(Body Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	CCMii(Cruise Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	CMR(Camera Module Rear)																																															
MONDEO	2010 MY	2.0L	DIESEL	DDM(Driver's Door Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	DSM(Driver's Seat Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	HCM(Headlamp Control Module)														V																																	
MONDEO	2010 MY	2.0L	DIESEL	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2010 MY	2.0L	DIESEL	IPC(Instrument Panel Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PAM(Parking Aid Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PBM(Parking Brake Control Module)							V																																								
MONDEO	2010 MY	2.0L	DIESEL	PDM(Passenger's Door Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	PSCM(Power Steering Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	RCM(Restraint Control Module)								V																																							
MONDEO	2010 MY	2.0L	DIESEL	RFA(Remote Function Actuator)																																															
MONDEO	2010 MY	2.0L	DIESEL	SASM(Steering Angle Sensor Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	SRM(Speech Recognition Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	TCM(Transmission Control Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	TRM(Trailer Module)																																															
MONDEO	2010 MY	2.0L	DIESEL	VDM(Vehicle Dynamic Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																															
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																															
MONDEO	2010 MY	2.3L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2010 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)							V																																									
MONDEO	2010 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																
MONDEO	2010 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2010 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)								V																																								
MONDEO	2010 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	RCM(Restraint Control Module)									V																																							
MONDEO	2010 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2010 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	TCM(Transmission Control Module)										V	V	V																																				
MONDEO	2010 MY	2.3L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																
MONDEO	2010 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA													V																																			
MONDEO	2010 MY	2.5L GASOLINE	SYSTEM SEARCH																																																
MONDEO	2010 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																
MONDEO	2010 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2010 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2010 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2010 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2010 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	RCM(Restraint Control Module)									V																																								
MONDEO	2010 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2010 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2010 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA												V																																					
MONDEO	2009 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)														V																																		
MONDEO	2009 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)							V																																									
MONDEO	2009 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)								V																																								
MONDEO	2009 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																
MONDEO	2009 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
MONDEO	2009 MY	1.8L DIESEL	SYSTEM SEARCH																																																
MONDEO	2009 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)							V							V																																		
MONDEO	2009 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	BCMii(Body Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																																
MONDEO	2009 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	1.8L DIESEL	PBM(Parking Brake Control Module)								V																																								
MONDEO	2009 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																
MONDEO	2009 MY	1.8L DIESEL	RCM(Restraint Control Module)									V																																							
MONDEO	2009 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	1.8L DIESEL	TRM(Trailer Module)																																																
MONDEO	2009 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																
MONDEO	2009 MY	2.0L DIESEL	SYSTEM SEARCH																																																
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)							V							V																																		
MONDEO	2009 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)									V																																							
MONDEO	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																																
MONDEO	2009 MY	2.0L DIESEL	CMR(Camera Module Rear)																																																
MONDEO	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																																																
MONDEO	2009 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																																
MONDEO	2009 MY	2.0L DIESEL	HCM(Headlamp Control Module)															V																																	
MONDEO	2009 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2009 MY	2.0L DIESEL	PAM(Parking Aid Module)																																																
MONDEO	2009 MY	2.0L DIESEL	PBM(Parking Brake Control Module)								V																																								
MONDEO	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																																
MONDEO	2009 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2009 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																																	
MONDEO	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	TRM(Trailer Module)																																																	
MONDEO	2009 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2009 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)							V																																										
MONDEO	2009 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2009 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2009 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)								V																																									
MONDEO	2009 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	RCM(Restraint Control Module)									V																																								
MONDEO	2009 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2009 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	TCM(Transmission Control Module)										V	V	V																																					
MONDEO	2009 MY	2.3L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																	
MONDEO	2009 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA													V																																				
MONDEO	2009 MY	2.5L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2009 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2009 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2009 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2009 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2009 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2009 MY	2.5L GASOLINE	RCM(Restraint Control Module)									V																																							
MONDEO	2009 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																
MONDEO	2009 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	TRM(Trailer Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																
MONDEO	2009 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA													V																																			
MONDEO	2008 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)													V																																			
MONDEO	2008 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)							V																																									
MONDEO	2008 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)								V																																								
MONDEO	2008 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																
MONDEO	2008 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																
MONDEO	2008 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2008 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)							V							V																																			
MONDEO	2008 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	BCMii(Body Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2008 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
MONDEO	2008 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2008 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	PBM(Parking Brake Control Module)								V																																									
MONDEO	2008 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	RCM(Restraint Control Module)									V																																								
MONDEO	2008 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																	
MONDEO	2008 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	TRM(Trailer Module)																																																	
MONDEO	2008 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2008 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)							V																																										
MONDEO	2008 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2008 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2008 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)								V																																									
MONDEO	2008 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	RCM(Restraint Control Module)									V																																								
MONDEO	2008 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2008 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	TCM(Transmission Control Module)										V	V	V																																					
MONDEO	2008 MY	2.3L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																	
MONDEO	2008 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA													V																																				
MONDEO	2008 MY	2.5L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2008 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2008 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2008 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2008 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2008 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	RCM(Restraint Control Module)									V																																								
MONDEO	2008 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2008 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2008 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA													V																																				
MONDEO	2007 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)														V																																		
MONDEO	2007 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)							V																																									
MONDEO	2007 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)								V																																								
MONDEO	2007 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																																
MONDEO	2007 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2007 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2007 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)							V							V																																			
MONDEO	2007 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	BCMii(Body Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	CMR(Camera Module Rear)																																																	
MONDEO	2007 MY	1.8L DIESEL	DDM(Driver's Door Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2007 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	PAM(Parking Aid Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	PBM(Parking Brake Control Module)								V																																									
MONDEO	2007 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	RCM(Restraint Control Module)									V																																								
MONDEO	2007 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																																	
MONDEO	2007 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	TRM(Trailer Module)																																																	
MONDEO	2007 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2007 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)							V																																										
MONDEO	2007 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2007 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2007 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)								V																																									
MONDEO	2007 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	RCM(Restraint Control Module)									V																																								
MONDEO	2007 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2007 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
MONDEO	2007 MY	2.3L GASOLINE	TCM(Transmission Control Module)										V	V	V																																					
MONDEO	2007 MY	2.3L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																																	
MONDEO	2007 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA													V																																				
MONDEO	2007 MY	2.5L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2007 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2007 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	BCMii(Body Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																																	
MONDEO	2007 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																	
MONDEO	2007 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	RCM(Restraint Control Module)									V																																								
MONDEO	2007 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																																	
MONDEO	2007 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	TRM(Trailer Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																	
MONDEO	2007 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA													V																																				
MONDEO	2003 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2003 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																V																																	
MONDEO	2003 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2003 MY	2.0L DIESEL	CSM(Central Security Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2003 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2003 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																	
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMli
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																	
MONDEO	2003 MY	2.0L DIESEL	ACM(Audio Control Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	CDP(Compact Disc Player)																																																	
MONDEO	2003 MY	2.0L DIESEL	GDM(Generic Display Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	NAV(Navigation System)																																																	
MONDEO	2003 MY	2.0L DIESEL	RETM(Rear Entertainment Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2003 MY	2.0L DIESEL	ICU(Injector Control Unit)																																																	
MONDEO	2003 MY	2.0L DIESEL	PATS(Passive Anti Theft System)																																																	
MONDEO	2002 MY	2.0L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2002 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																V																																	
MONDEO	2002 MY	2.0L DIESEL	TCM(Transmission Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2002 MY	2.0L DIESEL	CSM(Central Security Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2002 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2002 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																	
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																	
MONDEO	2002 MY	2.0L DIESEL	ACM(Audio Control Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	CDP(Compact Disc Player)																																																	
MONDEO	2002 MY	2.0L DIESEL	GDM(Generic Display Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	NAV(Navigation System)																																																	
MONDEO	2002 MY	2.0L DIESEL	RETM(Rear Entertainment Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																																	
MONDEO	2002 MY	2.0L DIESEL	ICU(Injector Control Unit)																																																	
MONDEO	2002 MY	2.0L DIESEL	PATS(Passive Anti Theft System)																																																	
MONDEO	2002 MY	2.0L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2002 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2002 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2002 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2002 MY	2.0L GASOLINE	GEM(Generic Electronic Module)																																																	
MONDEO	2002 MY	2.0L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2002 MY	2.0L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2001 MY	2.0L DIESEL	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
MONDEO	2001 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2001 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2001 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
MONDEO	2001 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																																	
MONDEO	2001 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																																	
MONDEO	2001 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																																	
MONDEO	2001 MY	2.0L DIESEL	RCM(Restraint Control Module)																																																	
MONDEO	2001 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																																	
MONDEO	2001 MY	2.0L DIESEL	ACM(Audio Control Module)																																																	
MONDEO	2001 MY	2.0L GASOLINE	SYSTEM SEARCH																																																	
MONDEO	2001 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)																																																	
MONDEO	2001 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																																	
MONDEO	2001 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																																	
MONDEO	2001 MY	2.0L GASOLINE	GEM(Generic Electronic Module)																																																	
MONDEO	2001 MY	2.0L GASOLINE	HCM(Headlamp Control Module)																																																	
MONDEO	2001 MY	2.0L GASOLINE	RCM(Restraint Control Module)																																																	
MONDEO	2000 MY	1.8L	SYSTEM SEARCH																																																	
MONDEO	2000 MY	1.8L	PCM(PowerTrain Control Module)																																																	
MONDEO	2000 MY	1.8L	ABS(Anti-Lock Brake System)																																																	
MONDEO	2000 MY	1.8L	CSM(Central Security Module)																																																	
MONDEO	2000 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	2000 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	2000 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	2000 MY	1.8L DIESEL	CSM(Central Security Module)																																																	
MONDEO	2000 MY	1.8L DIESEL	Passive Antitheft																																																	
MONDEO	2000 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																	
MONDEO	2000 MY	2.0L	SYSTEM SEARCH																																																	
MONDEO	2000 MY	2.0L	PCM(PowerTrain Control Module)																																																	
MONDEO	2000 MY	2.0L	ABS(Anti-Lock Brake System)																																																	
MONDEO	2000 MY	2.0L	CSM(Central Security Module)																																																	
MONDEO	2000 MY	2.5L	SYSTEM SEARCH																																																	
MONDEO	2000 MY	2.5L	PCM(PowerTrain Control Module)																																																	
MONDEO	2000 MY	2.5L	ABS(Anti-Lock Brake System)																																																	
MONDEO	2000 MY	2.5L	CSM(Central Security Module)																																																	
MONDEO	1999 MY	1.8L	SYSTEM SEARCH																																																	
MONDEO	1999 MY	1.8L	PCM(PowerTrain Control Module)																																																	
MONDEO	1999 MY	1.8L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1999 MY	1.8L	CSM(Central Security Module)																																																	
MONDEO	1999 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	1999 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
MONDEO	1999 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	1999 MY	1.8L DIESEL	CSM(Central Security Module)																																																	
MONDEO	1999 MY	1.8L DIESEL	Passive Antitheft																																																	
MONDEO	1999 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																	
MONDEO	1999 MY	2.0L	SYSTEM SEARCH																																																	
MONDEO	1999 MY	2.0L	PCM(PowerTrain Control Module)																																																	
MONDEO	1999 MY	2.0L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1999 MY	2.0L	CSM(Central Security Module)																																																	
MONDEO	1999 MY	2.5L	SYSTEM SEARCH																																																	
MONDEO	1999 MY	2.5L	PCM(PowerTrain Control Module)																																																	
MONDEO	1999 MY	2.5L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1999 MY	2.5L	CSM(Central Security Module)																																																	
MONDEO	1998 MY	1.8L	SYSTEM SEARCH																																																	
MONDEO	1998 MY	1.8L	PCM(PowerTrain Control Module)																																																	
MONDEO	1998 MY	1.8L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1998 MY	1.8L	CSM(Central Security Module)																																																	
MONDEO	1998 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	1998 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	1998 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	1998 MY	1.8L DIESEL	CSM(Central Security Module)																																																	
MONDEO	1998 MY	1.8L DIESEL	Passive Antitheft																																																	
MONDEO	1998 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																	
MONDEO	1998 MY	2.0L	SYSTEM SEARCH																																																	
MONDEO	1998 MY	2.0L	PCM(PowerTrain Control Module)																																																	
MONDEO	1998 MY	2.0L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1998 MY	2.0L	CSM(Central Security Module)																																																	
MONDEO	1998 MY	2.5L	SYSTEM SEARCH																																																	
MONDEO	1998 MY	2.5L	PCM(PowerTrain Control Module)																																																	
MONDEO	1998 MY	2.5L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1998 MY	2.5L	CSM(Central Security Module)																																																	
MONDEO	1997 MY	1.8L	PCM(PowerTrain Control Module)																																																	
MONDEO	1997 MY	1.8L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1997 MY	1.8L DIESEL	SYSTEM SEARCH																																																	
MONDEO	1997 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																																	
MONDEO	1997 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																																	
MONDEO	1997 MY	1.8L DIESEL	Passive Antitheft																																																	
MONDEO	1997 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																																	
MONDEO	1997 MY	2.0L	PCM(PowerTrain Control Module)																																																	
MONDEO	1997 MY	2.0L	ABS(Anti-Lock Brake System)																																																	
MONDEO	1997 MY	2.5L	PCM(PowerTrain Control Module)																																																	
MONDEO	1997 MY	2.5L	ABS(Anti-Lock Brake System)																																																	
MOUNTAINEER	2010 MY	4.6L	SYSTEM SEARCH																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
MOUNTAINEER	2010 MY	4.6L	PCM(Powertrain Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	TCM(Transmission Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	4X4(4x4 Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
MOUNTAINEER	2010 MY	4.6L	ACM(Audio Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
MOUNTAINEER	2010 MY	4.6L	GPSM(Global Positioning System Module)																																																	
MOUNTAINEER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
MOUNTAINEER	2010 MY	4.6L	DSM(Driver's Seat Module)																																																	
MOUNTAINEER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
MOUNTAINEER	2010 MY	4.6L	IC(Instrument Cluster)																																																	
MOUNTAINEER	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
MOUNTAINEER	2010 MY	4.6L	PAM(Parking Aid Module)																																																	
MOUNTAINEER	2010 MY	4.6L	PRB(Power Running Board)																																																	
MOUNTAINEER	2010 MY	4.6L	RCM(Restraint Control Module)																																																	
MOUNTAINEER	2010 MY	4.6L	RETM(Rear Entertainment Module)																																																	
MOUNTAINEER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
MOUNTAINEER	2009 MY	4.6L	SYSTEM SEARCH																																																	
MOUNTAINEER	2009 MY	4.6L	PCM(Powertrain Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	TCM(Transmission Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	4X4(4x4 Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																																	
MOUNTAINEER	2009 MY	4.6L	ACM(Audio Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																																	
MOUNTAINEER	2009 MY	4.6L	GPSM(Global Positioning System Module)																																																	
MOUNTAINEER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																																	
MOUNTAINEER	2009 MY	4.6L	DSM(Driver's Seat Module)																																																	
MOUNTAINEER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
MOUNTAINEER	2009 MY	4.6L	IC(Instrument Cluster)																																																	
MOUNTAINEER	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																																	
MOUNTAINEER	2009 MY	4.6L	PAM(Parking Aid Module)																																																	
MOUNTAINEER	2009 MY	4.6L	PRB(Power Running Board)																																																	
MOUNTAINEER	2009 MY	4.6L	RCM(Restraint Control Module)																																																	
MOUNTAINEER	2009 MY	4.6L	RETM(Rear Entertainment Module)																																																	
MOUNTAINEER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																																	
MUSTANG	4.0L V6 SOHC			SYSTEM SEARCH																																																
MUSTANG	4.0L V6 SOHC			PCM(Powertrain Control Module)																																																	
MUSTANG	4.0L V6 SOHC			ABS(Anti-Lock Brake System)																																																	
MUSTANG	4.0L V6 SOHC			ACM(Audio Control Module)																																																	
MUSTANG	4.0L V6 SOHC			APIM(Accessory Protocol Interface Module)																																																	
MUSTANG	4.0L V6 SOHC			GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
MUSTANG	4.0L V6 SOHC			RCM(Restraint Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
MUSTANG	4.0L V6 SOHC			SDARS(Satellite Digital Audio Receiver System)																																																
MUSTANG	4.0L V6 SOHC			IC(Instrument Cluster)																																																
TAURUS	2011 MY	3.5L	SYSTEM SEARCH																																																
TAURUS	2011 MY	3.5L	PCM(PowerTrain Control Module)																																																
TAURUS	2011 MY	3.5L	4X4(4x4 Control Module)																																																
TAURUS	2011 MY	3.5L	ABS(Anti-Lock Brake System)																																																
TAURUS	2011 MY	3.5L	ACM(Audio Control Module)																																																
TAURUS	2011 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																
TAURUS	2011 MY	3.5L	C-CM(Cruise Control Module)																																																
TAURUS	2011 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																	V																																
TAURUS	2011 MY	3.5L	DDM(Driver's Door Module)																		V																															
TAURUS	2011 MY	3.5L	DSM(Driver's Seat Module)																																																
TAURUS	2011 MY	3.5L	DSP(Digital Signal Processing Module)																																																
TAURUS	2011 MY	3.5L	FCIM(Front Controls Interface Module)																																																
TAURUS	2011 MY	3.5L	FDIM(Front Display Interface Module)																																																
TAURUS	2011 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
TAURUS	2011 MY	3.5L	GPSM(Global Positioning System Module)																																																
TAURUS	2011 MY	3.5L	HCM(Headlamp Control Module)																																																
TAURUS	2011 MY	3.5L	HCM-2(Headlamp Control Module2)																																																
TAURUS	2011 MY	3.5L	HUD(Head Up Display)																																																
TAURUS	2011 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																
TAURUS	2011 MY	3.5L	ILCM(Interior Lighting Control Module)																																																
TAURUS	2011 MY	3.5L	IPC(Instrument Panel Control Module)																			V																														
TAURUS	2011 MY	3.5L	OCSM(Occupant Classification System Module)																																																
TAURUS	2011 MY	3.5L	PAM(Parking Aid Module)																																																
TAURUS	2011 MY	3.5L	PSCM(Power Steering Control Module)																																																
TAURUS	2011 MY	3.5L	RCM(Restraint Control Module)																																																
TAURUS	2011 MY	3.5L	RETM(Rear Entertainment Module)																																																
TAURUS	2011 MY	3.5L	RFA(Remote Function Actuator)																																																
TAURUS	2011 MY	3.5L	SASM(Steering Angle Sensor Module)																																																
TAURUS	2011 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																
TAURUS	2011 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																
TAURUS	2010 MY	3.5L	SYSTEM SEARCH																																																
TAURUS	2010 MY	3.5L	PCM(PowerTrain Control Module)																																																
TAURUS	2010 MY	3.5L	4X4(4x4 Control Module)																																																
TAURUS	2010 MY	3.5L	ABS(Anti-Lock Brake System)																																																
TAURUS	2010 MY	3.5L	ACM(Audio Control Module)																																																
TAURUS	2010 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																
TAURUS	2010 MY	3.5L	C-CM(Cruise Control Module)																																																
TAURUS	2010 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																	V																																
TAURUS	2010 MY	3.5L	DDM(Driver's Door Module)																		V																															
TAURUS	2010 MY	3.5L	DSM(Driver's Seat Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
TAURUS	2010 MY	3.5L	DSP(Digital Signal Processing Module)																																																
TAURUS	2010 MY	3.5L	FCIM(Front Controls Interface Module)																																																
TAURUS	2010 MY	3.5L	FDIM(Front Display Interface Module)																																																
TAURUS	2010 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
TAURUS	2010 MY	3.5L	GPSM(Global Positioning System Module)																																																
TAURUS	2010 MY	3.5L	HCM(Headlamp Control Module)																																																
TAURUS	2010 MY	3.5L	HCM-2(Headlamp Control Module2)																																																
TAURUS	2010 MY	3.5L	HUD(Head Up Display)																																																
TAURUS	2010 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																
TAURUS	2010 MY	3.5L	ILCM(Interior Lighting Control Module)																																																
TAURUS	2010 MY	3.5L	IPC(Instrument Panel Control Module)																			V																														
TAURUS	2010 MY	3.5L	OCSM(Occupant Classification System Module)																																																
TAURUS	2010 MY	3.5L	PAM(Parking Aid Module)																																																
TAURUS	2010 MY	3.5L	PSCM(Power Steering Control Module)																																																
TAURUS	2010 MY	3.5L	RCM(Restraint Control Module)																																																
TAURUS	2010 MY	3.5L	RETM(Rear Entertainment Module)																																																
TAURUS	2010 MY	3.5L	RFA(Remote Function Actuator)																																																
TAURUS	2010 MY	3.5L	SASM(Steering Angle Sensor Module)																																																
TAURUS	2010 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																
TAURUS	2010 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																
TAURUS	2009 MY	3.5L	SYSTEM SEARCH																																																
TAURUS	2009 MY	3.5L	PCM(PowerTrain Control Module)																																																
TAURUS	2009 MY	3.5L	4X4(4x4 Control Module)																																																
TAURUS	2009 MY	3.5L	ABS(Anti-Lock Brake System)																																																
TAURUS	2009 MY	3.5L	ACM(Audio Control Module)																																																
TAURUS	2009 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																
TAURUS	2009 MY	3.5L	C-CM(Cruise Control Module)																																																
TAURUS	2009 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																	V																															
TAURUS	2009 MY	3.5L	DDM(Driver's Door Module)																		V																														
TAURUS	2009 MY	3.5L	DSM(Driver's Seat Module)																																																
TAURUS	2009 MY	3.5L	DSP(Digital Signal Processing Module)																																																
TAURUS	2009 MY	3.5L	FCIM(Front Controls Interface Module)																																																
TAURUS	2009 MY	3.5L	FDIM(Front Display Interface Module)																																																
TAURUS	2009 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																
TAURUS	2009 MY	3.5L	GPSM(Global Positioning System Module)																																																
TAURUS	2009 MY	3.5L	HCM(Headlamp Control Module)																																																
TAURUS	2009 MY	3.5L	HCM-2(Headlamp Control Module2)																																																
TAURUS	2009 MY	3.5L	HUD(Head Up Display)																																																
TAURUS	2009 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																
TAURUS	2009 MY	3.5L	ILCM(Interior Lighting Control Module)																																																
TAURUS	2009 MY	3.5L	IPC(Instrument Panel Control Module)																			V																														
TAURUS	2009 MY	3.5L	OCSM(Occupant Classification System Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
TAURUS	2009 MY	3.5L	PAM(Parking Aid Module)																																																	
TAURUS	2009 MY	3.5L	PSCM(Power Steering Control Module)																																																	
TAURUS	2009 MY	3.5L	RCM(Restraint Control Module)																																																	
TAURUS	2009 MY	3.5L	RETM(Rear Entertainment Module)																																																	
TAURUS	2009 MY	3.5L	RFA(Remote Function Actuator)																																																	
TAURUS	2009 MY	3.5L	SASM(Steering Angle Sensor Module)																																																	
TAURUS	2009 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																	
TAURUS	2009 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																	
TAURUS	2008 MY	3.5L	SYSTEM SEARCH																																																	
TAURUS	2008 MY	3.5L	PCM(PowerTrain Control Module)																																																	
TAURUS	2008 MY	3.5L	4X4(4x4 Control Module)																																																	
TAURUS	2008 MY	3.5L	ABS(Anti-Lock Brake System)																																																	
TAURUS	2008 MY	3.5L	ACM(Audio Control Module)																																																	
TAURUS	2008 MY	3.5L	APIM(Accessory Protocol Interface Module)																																																	
TAURUS	2008 MY	3.5L	C-CM(Cruise Control Module)																																																	
TAURUS	2008 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																	V																																
TAURUS	2008 MY	3.5L	DDM(Driver's Door Module)																		V																															
TAURUS	2008 MY	3.5L	DSM(Driver's Seat Module)																																																	
TAURUS	2008 MY	3.5L	DSP(Digital Signal Processing Module)																																																	
TAURUS	2008 MY	3.5L	FCIM(Front Controls Interface Module)																																																	
TAURUS	2008 MY	3.5L	FDIM(Front Display Interface Module)																																																	
TAURUS	2008 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																																	
TAURUS	2008 MY	3.5L	GPSM(Global Positioning System Module)																																																	
TAURUS	2008 MY	3.5L	HCM(Headlamp Control Module)																																																	
TAURUS	2008 MY	3.5L	HCM-2(Headlamp Control Module2)																																																	
TAURUS	2008 MY	3.5L	HUD(Head Up Display)																																																	
TAURUS	2008 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																																	
TAURUS	2008 MY	3.5L	ILCM(Interior Lighting Control Module)																																																	
TAURUS	2008 MY	3.5L	IPC(Instrument Panel Control Module)																			V																															
TAURUS	2008 MY	3.5L	OCSM(Occupant Classification System Module)																																																	
TAURUS	2008 MY	3.5L	PAM(Parking Aid Module)																																																	
TAURUS	2008 MY	3.5L	PSCM(Power Steering Control Module)																																																	
TAURUS	2008 MY	3.5L	RCM(Restraint Control Module)																																																	
TAURUS	2008 MY	3.5L	RETM(Rear Entertainment Module)																																																	
TAURUS	2008 MY	3.5L	RFA(Remote Function Actuator)																																																	
TAURUS	2008 MY	3.5L	SASM(Steering Angle Sensor Module)																																																	
TAURUS	2008 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																																	
TAURUS	2008 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																																	
TAURUS	1998 MY	SYSTEM SEARCH																																																		
TAURUS	1998 MY	PCM(PowerTrain Control Module)																																																		
TAURUS	1998 MY	ABS(Anti-Lock Brake System)																																																		
TAURUS	1998 MY	RCM(Restraint Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
TAURUS	1998 MY	RIM(Remote Immobilizer Module)																																																	
TAURUS	1997 MY	SYSTEM SEARCH																																																	
TAURUS	1997 MY	PCM(PowerTrain Control Module)																																																	
TAURUS	1997 MY	ABS(Anti-Lock Brake System)																																																	
TAURUS	1997 MY	RCM(Restraint Control Module)																																																	
TAURUS	1997 MY	RIM(Remote Immobilizer Module)																																																	
TAURUS	1996 MY	SYSTEM SEARCH																																																	
TAURUS	1996 MY	PCM(PowerTrain Control Module)																																																	
TAURUS	1996 MY	ABS(Anti-Lock Brake System)																																																	
TAURUS	1996 MY	RCM(Restraint Control Module)																																																	
TAURUS	1996 MY	RIM(Remote Immobilizer Module)																																																	
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	SYSTEM SEARCH																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PCM(PowerTrain Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	TCM(Transmission Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ABS(Anti-Lock Brake System)																			V																														
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ACM(Audio Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	APIM(Accessory Protocol Interface Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	BEM(Body Electronic Module)																				V																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	FCIM(Front Controls Interface Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GPSM(Global Positioning System Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GWM(Gateway Module A)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	HIM(HVAC Integrated Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	IPC(Instrument Panel Control Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PAM(Parking Aid Module)																																																
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PSCM(Power Steering Control Module)																					V																												
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	RCM(Restraint Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	SYSTEM SEARCH																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PCM(Powertrain Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	TCM(Transmission Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)																						V	V																										
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)																								V																								
TERRITORY	2010~	4.0L GASOLINE	SY	ACM(Audio Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PSCM(Power Steering Control Module)																					V																												
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)																				V																												
TERRITORY	2010~	4.0L GASOLINE	SY	HIM(HVAC Integrated Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)																								V	V	V	V																					
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)																												V																				
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)																																																
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMli
TERRITORY	2010~	4.0L GASOLINE	SY	FDIM(Front Display Interface Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	SYSTEM SEARCH																																															
TERRITORY	2010~	2.7L DIESEL	SZ	PCM(Powertrain Control Module)																													V																		
TERRITORY	2010~	2.7L DIESEL	SZ	ABS(Anti-Lock Brake System)																							V																								
TERRITORY	2010~	2.7L DIESEL	SZ	ACM(Audio Control Module)																												V																			
TERRITORY	2010~	2.7L DIESEL	SZ	AWD(All Wheel Drive Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	BEM(Body Electronic Module)																				V																												
TERRITORY	2010~	2.7L DIESEL	SZ	FDIM(Front Display Interface Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	HIM(HVAC Intergrated Module)																														V																	
TERRITORY	2010~	2.7L DIESEL	SZ	IPC(Instrument Panel Control Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	PAM(Parking Aid Module)																															V																
TERRITORY	2010~	2.7L DIESEL	SZ	PSCM(Power Steering Control Module)																					V																										
TERRITORY	2010~	2.7L DIESEL	SZ	RCM(Restraint Control Module)																																															
TERRITORY	2010~	2.7L DIESEL	SZ	TCM(Transmission Control Module)																																															
TERRITORY	2009~2010	SYSTEM SEARCH																																																	
TERRITORY	2009~2010	PCM(PowerTrain Control Module)																																																	
TERRITORY	2009~2010	TCM(Transmission Control Module)																																																	
TERRITORY	2009~2010	ABS(Anti-Lock Brake System)																																		V															
TERRITORY	2009~2010	RCM(Restraint Control Module)																																																	
TERRITORY	2009~2010	BEM(Body Electronic Module)																																			V	V	V	V	V	V									
TERRITORY	2009~2010	IC(Instrument Cluster)																																																	
TERRITORY	2009~2010	HIM(HVAC Integrated Module)																																																	
TERRITORY	2009~2010	ACM(Audio Control Module)																																									V	V							
TERRITORY	2005~2009	SYSTEM SEARCH																																																	
TERRITORY	2005~2009	PCM(PowerTrain Control Module)																																																	
TERRITORY	2005~2009	TCM(Transmission Control Module)																																																	
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)																																		V															
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)																																																	
TERRITORY	2005~2009	RCM(Restraint Control Module)																																																	
TERRITORY	2005~2009	BEM(Body Electronic Module)																																			V	V	V	V	V	V									
TERRITORY	2005~2009	IC(Instrument Cluster)																																																	
TERRITORY	2005~2009	HIM(HVAC Integrated Module)																																																	
TERRITORY	2005~2009	ACM(Audio Control Module)																																									V	V							
TERRITORY	2004~2005	SYSTEM SEARCH																																																	
TERRITORY	2004~2005	PCM(PowerTrain Control Module)																																																	
TERRITORY	2004~2005	ABS(Anti-Lock Brake System)																																																	
TERRITORY	2004~2005	RCM(Restraint Control Module)																																																	
TERRITORY	2004~2005	BEM(Body Electronic Module)																																			V	V	V	V	V	V			V	V					
TERRITORY	2004~2005	IC(Instrument Cluster)																																																	
TERRITORY	2004~2005	HIM(HVAC Integrated Module)																																																	
TERRITORY	2004~2005	HIM(HVAC Integrated Module)																																																	
TERRITORY	2004~2005	ACM(Audio Control Module)																																									V	V							

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
TERRITORY	2004~2005	PAM(Parking Aid Module)																																																	
TRANSIT	1.6L DIESEL	SYSTEM SEARCH																																																	
TRANSIT	1.6L DIESEL	PCM(PowerTrain Control Module)																																												V	V	V	V	
TRANSIT	1.6L DIESEL	ABS(Anti-Lock Brake System)																																																	
TRANSIT	1.6L DIESEL	ACM(Audio Control Module)																																																	
TRANSIT	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)																																																	
TRANSIT	1.6L DIESEL	APIM(Accessory Protocol Interface Module)																																																	
TRANSIT	1.6L DIESEL	BCMii(Body Control Module)																																																	V
TRANSIT	1.6L DIESEL	DDM(Driver's Door Module)																																																	
TRANSIT	1.6L DIESEL	FCIM(Front Controls Interface Module)																																																	
TRANSIT	1.6L DIESEL	FDSM(Front Distance Sensing Module)																																																	
TRANSIT	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)																																																	
TRANSIT	1.6L DIESEL	GPSM(Global Positioning System Module)																																																	
TRANSIT	1.6L DIESEL	HCM(Headlamp Control Module)																																																	
TRANSIT	1.6L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																	
TRANSIT	1.6L DIESEL	IPM-B(Image Processing Module B)																																																	
TRANSIT	1.6L DIESEL	IPC(Instrument Panel Control Module)																																																	
TRANSIT	1.6L DIESEL	PAM(Parking Aid Module)																																																	
TRANSIT	1.6L DIESEL	PDM(Passenger's Door Module)																																																	
TRANSIT	1.6L DIESEL	PSCM(Power Steering Control Module)																																																	
TRANSIT	1.6L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	1.6L DIESEL	SASM(Steering Angle Sensor Module)																																																	
TRANSIT	1.6L DIESEL	TRM(Trailer Module)																																																	
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)																																																
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)																																																
TRANSIT	2.0L	SYSTEM SEARCH																																																		
TRANSIT	2.0L	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.0L	PATS(Passive Anti Theft System)																																																		
TRANSIT	2.0L	ASM(Auto Shift Manual)																																																		
TRANSIT	2.0L	ABS(Anti-Lock Brake System)																																																		
TRANSIT	2.0L	HEC(Hybrid Electrical Cluster)																																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SYSTEM SEARCH																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ACM(Audio Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	APIM(Accessory Protocol Interface Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	AHCM(Auxiliary Heater Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	CCMii(Cruise Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FCDIM(Front Control/Display Interface Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	GPSM(Global Positioning System Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	HCM(Headlamp Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-A(Image Processing Module A)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-B(Image Processing Module B)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FFH(Fuel Fired Coolant Heating Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PRB(Power Running Board)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SRM(Speech Recognition Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SASM(Steering Angle Sensor Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TBC(Trailer Brake Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TRM(Trailer Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SYSTEM SEARCH																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ACM(Audio Control Module)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	APIM(Accessory Protocol Interface Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	AHCM(Auxiliary Heater Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	CCMii(Cruise Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FCDIM(Front Control/Display Interface Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	GPSM(Global Positioning System Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	HCM(Headlamp Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-A(Image Processing Module A)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-B(Image Processing Module B)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FFH(Fuel Fired Coolant Heating Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PRB(Power Running Board)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SRM(Speech Recognition Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SASM(Steering Angle Sensor Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TBC(Trailer Brake Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TRM(Trailer Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	SYSTEM SEARCH																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PATS(Passive Anti Theft System)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ASM(Auto Shift Manual)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	HEC(Hybrid Electrical Cluster)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	BCMii(Body Control Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	CSM(Central Security Module)																																																
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ACM(Audio Control Module)																																																
TRANSIT	2.3L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.3L DIESEL	PATS(Passive Anti Theft System)																																																		
TRANSIT	2.3L DIESEL	ASM(Auto Shift Manual)																																																		
TRANSIT	2.3L DIESEL	ABS(Anti-Lock Brake System)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
TRANSIT	2.3L DIESEL	RCM(Restraint Control Module)																																																		
TRANSIT	2.3L DIESEL	HEC(Hybrid Electrical Cluster)																																																		
TRANSIT	2.3L DIESEL	IPC(Instrument Panel Control Module)																																																		
TRANSIT	2.3L DIESEL	BCMii(Body Control Module)																																																		
TRANSIT	2.3L DIESEL	ACM(Audio Control Module)																																																		
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	BCMii(Body Control Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	IPC(Instrument Panel Control Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																																	
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)																																																	
TRANSIT	2.4L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.4L DIESEL	PATS(Passive Anti Theft System)																																																		
TRANSIT	2.4L DIESEL	ASM(Auto Shift Manual)																																																		
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)																																																		
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)																																																		
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)																																																		
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)																																																		
TRANSIT	2.4L DIESEL	HEC(Hybrid Electrical Cluster)																																																		
TRANSIT	2.4L DIESEL	IPC(Instrument Panel Control Module)																																																		
TRANSIT	2.4L DIESEL	BCMii(Body Control Module)																																																		
TRANSIT	2.4L DIESEL	CSM(Central Security Module)																																																		
TRANSIT	2.4L DIESEL	ACM(Audio Control Module)																																																		
TRANSIT	2.5L DIESEL	SYSTEM SEARCH																																																		
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)																																																		
TRANSIT	2.5L DIESEL	PATS(Passive Anti Theft System)																																																		
TRANSIT	2.5L DIESEL	ASM(Auto Shift Manual)																																																		
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																																																	
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																																																	
TRANSIT	2.5L DIESEL	RCM(Restraint Control Module)																																																		
TRANSIT	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																																																		
TRANSIT	2.5L DIESEL	CSM(Central Security Module)																																																		
TRANSIT	2.5L DIESEL	Passive Antitheft																																																		
TRANSIT	2.5L DIESEL	RIM(Remote Immobilizer Module)																																																		
TRANSIT	2.5L DIESEL	ACM(Audio Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
TRANSIT	3.2L DIESEL	SYSTEM SEARCH																																																	
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)																																																	
TRANSIT	3.2L DIESEL	ABS(Anti-Lock Brake System)																																																	
TRANSIT	3.2L DIESEL	ACM(Audio Control Module)																																																	
TRANSIT	3.2L DIESEL	BCMii(Body Control Module)																																																	
TRANSIT	3.2L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																																	
TRANSIT	3.2L DIESEL	IPC(Instrument Panel Control Module)																																																	
TRANSIT	3.2L DIESEL	PAM(Parking Aid Module)																																																	
TRANSIT	3.2L DIESEL	RCM(Restraint Control Module)																																																	
TRANSIT	3.2L DIESEL	SRM(Speech Recognition Module)																																																	
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)																																																
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)																																																
RANGER	2.2 Diesel	SYSTEM SEARCH																																																	
RANGER	2.2 Diesel	PCM(PowerTrain Control Module)																																																	
RANGER	2.2 Diesel	ABS(Anti-Lock Brake System)																																																	
RANGER	2.2 Diesel	ACM(Audio Control Module)																																																	
RANGER	2.2 Diesel	BCMii(Body Control Module)																																																	
RANGER	2.2 Diesel	DDM(Driver's Door Module)																																																	
RANGER	2.2 Diesel	FCDIM(Front Control/Display Interface Module)																																																	
RANGER	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
RANGER	2.2 Diesel	IPC(Instrument Panel Control Module)																																																	
RANGER	2.2 Diesel	PAM(Parking Aid Module)																																																	
RANGER	2.2 Diesel	PDM(Passenger's Door Module)																																																	
RANGER	2.2 Diesel	RCM(Restraint Control Module)																																																	
RANGER	2.2 Diesel	SRM(Speech Recognition Module)																																																	
RANGER	2.2 Diesel	TBM(Tracking And Blocking Module)																																																	
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																	
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																	
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																																	
RANGER	2.2 Diesel	TRM(Trailer Module)																																																	
RANGER	2.2 Diesel	PATS(Passive anti theft system)-BETA																																				V													
RANGER	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																																	
RANGER	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																																																	
RANGER	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																																																	
RANGER	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																																																	
RANGER	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																																																	
RANGER	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)-BETA																																				V													
RANGER	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																																	
RANGER	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																																																	
RANGER	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																																																	
RANGER	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																																																	
RANGER	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																																																	
RANGER	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)-BETA																																				V													
RANGER	3.2 Diesel	~ 2015	SYSTEM SEARCH																																																
RANGER	3.2 Diesel	~ 2015	PCM(PowerTrain Control Module)																																																
RANGER	3.2 Diesel	~ 2015	ABS(Anti-Lock Brake System)																																																
RANGER	3.2 Diesel	~ 2015	ACM(Audio Control Module)																																																
RANGER	3.2 Diesel	~ 2015	BCMii(Body Control Module)																																																
RANGER	3.2 Diesel	~ 2015	DDM(Driver's Door Module)																																																
RANGER	3.2 Diesel	~ 2015	FCDIM(Front Control/Display Interface Module)																																																
RANGER	3.2 Diesel	~ 2015	HVAC(Heating Ventilation Air Conditioning)																																																
RANGER	3.2 Diesel	~ 2015	IPC(Instrument Panel Control Module)																																																
RANGER	3.2 Diesel	~ 2015	PAM(Parking Aid Module)																																																
RANGER	3.2 Diesel	~ 2015	PDM(Passenger's Door Module)																																																
RANGER	3.2 Diesel	~ 2015	RCM(Restraint Control Module)																																																
RANGER	3.2 Diesel	~ 2015	SRM(Speech Recognition Module)																																																
RANGER	3.2 Diesel	~ 2015	TBM(Tracking And Blocking Module)																																																
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																																
RANGER	3.2 Diesel	~ 2015	TRM(Trailer Module)																																																
RANGER	3.2 Diesel	~ 2015	PATS(Passive anti theft system)-BETA																																			V													

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMii
RANGER	3.2 Diesel	2015 ~	SYSTEM SEARCH																																																		
RANGER	3.2 Diesel	2015 ~	PCM(PowerTrain Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	TCM(Transmission Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	ABS(Anti-Lock Brake System)																																																		
RANGER	3.2 Diesel	2015 ~	ACM(Audio Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	APIM(Accessory Protocol Interface Module)																																																		
RANGER	3.2 Diesel	2015 ~	ATCM(All Terrain Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	BCM(Body Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	C-CM(Cruise Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	DDM(Driver's Door Module)																																																		
RANGER	3.2 Diesel	2015 ~	FCDIM(Front Control/Display Interface Module)																																																		
RANGER	3.2 Diesel	2015 ~	FCIM(Front Controls Interface Module)																																																		
RANGER	3.2 Diesel	2015 ~	GPSM(Global Positioning System Module)																																																		
RANGER	3.2 Diesel	2015 ~	GWM(Gateway Module A)																																																		
RANGER	3.2 Diesel	2015 ~	HCM(Headlamp Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	HUD(Head Up Display)																																																		
RANGER	3.2 Diesel	2015 ~	IPC(Instrument Panel Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	IPM-A(Image Processing Module A)																																																		
RANGER	3.2 Diesel	2015 ~	PAM(Parking Aid Module)																																																		
RANGER	3.2 Diesel	2015 ~	PDM(Passenger's Door Module)																																																		
RANGER	3.2 Diesel	2015 ~	PSCM(Power Steering Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	RCM(Restraint Control Module)																																																		
RANGER	3.2 Diesel	2015 ~	RGTM(Rear Gate/Trunk Module)																																																		
RANGER	3.2 Diesel	2015 ~	RTM(Radio Transceiver Module)																																																		
RANGER	3.2 Diesel	2015 ~	SCCM(Streering Colume Control Module)		V																																																
RANGER	3.2 Diesel	2015 ~	TCU(Telemetic Control Unit Module)		V																																																
RANGER	3.2 Diesel	2015 ~	TRM(Trailer Module)																																																		
RANGER	2.5 Gasoline	SYSTEM SEARCH																																																			
RANGER	2.5 Gasoline	PCM(PowerTrain Control Module)																																																			
RANGER	2.5 Gasoline	ABS(Anti-Lock Brake System)																																																			
RANGER	2.5 Gasoline	ACM(Audio Control Module)																																																			
RANGER	2.5 Gasoline	BCMii(Body Control Module)																																																			
RANGER	2.5 Gasoline	DDM(Driver's Door Module)																																																			
RANGER	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																																																			
RANGER	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																																																			
RANGER	2.5 Gasoline	IPC(Instrument Panel Control Module)																																																			
RANGER	2.5 Gasoline	PAM(Parking Aid Module)																																																			
RANGER	2.5 Gasoline	PDM(Passenger's Door Module)																																																			
RANGER	2.5 Gasoline	RCM(Restraint Control Module)																																																			
RANGER	2.5 Gasoline	SRM(Speech Recognition Module)																																																			
RANGER	2.5 Gasoline	TBM(Tracking And Blocking Module)																																																			
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																	
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																																	
RANGER	2.5 Gasoline	TRM(Trailer Module)																																																	
RANGER	2.5 Gasoline	PATS(Passive anti theft system)-BETA																																				V													
BETA-TEST	FOCUS-1.6L Zetec Rocam	SYSTEM SEARCH																																																	
BETA-TEST	FOCUS-1.6L Zetec Rocam	PCM(PowerTrain Control Module)																																																	
BETA-TEST	FOCUS-1.6L Zetec Rocam	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	FOCUS-1.6L Zetec Rocam	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	FOCUS-1.6L Zetec Rocam	GEM(Generic Electronic Module)																																																	
BETA-TEST	FOCUS-1.6L Zetec Rocam	HCM(Headlamp Control Module)																																																	
BETA-TEST	FOCUS-1.6L Zetec Rocam	MC(Message Center)																																																	
BETA-TEST	FOCUS-1.6L Zetec Rocam	RCM(Restraint Control Module)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SYSTEM SEARCH																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ACM(Audio Control Module)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CDP(Compact Disc Player)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CMR(Camera Module Rear)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	D_DCU(Driver Door Control Unit)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EPS(Electronic Power Steering)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	FFH(Fuel Fired Coolant Heating Module)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	HCM(Headlamp Control Module)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	IC(Instrument Cluster)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PAM(Parking Aid Module)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PDM(Passenger's Door Module)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RCM(Restraint Control Module)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RETM(Rear Entertainment Module)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RKE(Remote Keyless Entry)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GDM(Generic Display Module)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	NAV(Navigation System)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RL_DCU(Rear Left Door Control Unit)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RR_DCU(Rear Right Door Control Unit)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)																																																	
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	TCM(Transmission Control Module)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	SYSTEM SEARCH																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PCM(PowerTrain Control Module)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ACM(Audio Control Module)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CDP(Compact Disc Player)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CMR(Camera Module Rear)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMli
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	D_DCU(Driver Door Control Unit)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EPS(Electronic Power Steering)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FACM(Fuel Additive Control Module)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	GEM(Generic Electronic Module)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	HCM(Headlamp Control Module)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	IC(Instrument Cluster)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PAM(Parking Aid Module)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PDM(Passenger's Door Module)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RCM(Restraint Control Module)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RETM(Rear Entertainment Module)																																																	
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RKE(Remote Keyless Entry)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SYSTEM SEARCH																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ACM(Audio Control Module)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	CDP(Compact Disc Player)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EPS(Electronic Power Steering)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GDM(Generic Display Module)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GEM(Generic Electronic Module)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	IC(Instrument Cluster)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	NAV(Navigation System)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PAM(Parking Aid Module)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PDM(Passenger's Door Module)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SRM(Speech Recognition Module)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	HCM(Headlamp Control Module)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RCM(Restraint Control Module)																																																	
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	TCM(Transmission Control Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SYSTEM SEARCH																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PCM(PowerTrain Control Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ACM(Audio Control Module)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	CDP(Compact Disc Player)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																																	
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EPS(Electronic Power Steering)																																																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMli
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GDM(Generic Display Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	NAV(Navigation System)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RL_DCU(Rear Left Door Control Unit)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RR_DCU(Rear Right Door Control Unit)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SRM(Speech Recognition Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PCM(Powertrain Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ACM(Audio Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	D_DCU(Driver Door Control Unit)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EPS(Electronic power steering)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	GEM(Generic Electronic Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TBM(Tracking and Blocking Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TCM(Transmission Control Module)																																																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PATS(Passive Anti Theft System)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	SYSTEM SEARCH																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CDP(Compact Disc Player)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CMR(Camera Module Rear)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	D_DCU(Driver Door Control Unit)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EPS(Electronic Power Steering)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FACM(Fuel Additive Control Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	GEM(Generic Electronic Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	HCM(Headlamp Control Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	IC(Instrument Cluster)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PDM(Passenger's Door Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PAM(Parking Aid Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RCM(Restraint Control Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RETM(Rear Entertainment Module)																																																		
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RKE(Remote Keyless Entry)																																																		
BETA-TEST	FUSION GASOLINE1.4L	SYSTEM SEARCH																																																		
BETA-TEST	FUSION GASOLINE1.4L	PCM(Powertrain Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FUSION GASOLINE1.4L	ACM(Audio Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	APIM(Accessory Protocol Interface Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	BCMii(Body Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	DDM(Driver's Door Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	FDSM(Front Distance Sensing Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	FCDIM(Front Control/Display Interface Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	GPSM(Global Positioning System Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	GWM(Gateway Module A)																																																		
BETA-TEST	FUSION GASOLINE1.4L	HVAC(Heating Ventilation Air Conditioning)																																																		
BETA-TEST	FUSION GASOLINE1.4L	IPC(Instrument Panel Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	PDM(Passenger's Door Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	PSCM(Power Steering Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	RCM(Restraint Control Module)																																																		
BETA-TEST	FUSION GASOLINE1.4L	RFA(Remote Function Actuator)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	TCM(Transmission Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IC(Instrument Cluster)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	GEM(Generic Electronic Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ACM(Audio Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	BCMii(Body Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	FCDIM(Front Control/Display Interface Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IPC(Instrument Panel Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PSCM(Power Steering Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RCM(Retraint Control Module)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RFA(Remote Function Actuator)																																																		
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SRM(Speech Recognition Module)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SYSTEM SEARCH																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMli
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	TCM(Transmission Control Module)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	IC(Instrument Cluster)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ACM(Audio Control Module)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)																																																		
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)																																																		
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																																																		
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	TCM(Transmission Control Module)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	IC(Instrument Cluster)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	ACM(Audio Control Module)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	GEM(Generic Electronic Module)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	SRM(Speech Recognition Module)																																																		
BETA-TEST	FIESTA 1.6L DURATEC 16V	PATS(Passive Anti Theft System)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SYSTEM SEARCH																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PCM(PowerTrain Control Module)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ACM(Audio Control Module)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	GEM(Generic Electronic Module)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	IC(Instrument Cluster)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SRM(Speech Recognition Module)																																																		
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PATS(Passive Anti Theft System)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	SYSTEM SEARCH																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PCM(PowerTrain Control Module)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	IC(Instrument Cluster)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RCM(Restraint Control Module)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RKE(Remote Keyless Entry)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	TCM(Transmission Control Module)																																																		
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PATS(Passive Anti Theft System)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	SYSTEM SEARCH																																																		
BETA-TEST	MONDEO-2.0L DIESEL	PCM(PowerTrain Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylunder 1	Reset the Fuel Injector Learned Values-Cylunder 2	Reset the Fuel Injector Learned Values-Cylunder 3	Reset the Fuel Injector Learned Values-Cylunder 4	Parameter Reset/Configuration BCMii
BETA-TEST	MONDEO-2.0L DIESEL	ABS(Anti-Lock Brake System)								V							V																																			
BETA-TEST	MONDEO-2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	BCMii(Body Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	CCMii(Cruise Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	CMR(Camera Module Rear)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	DDM(Driver's Door Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	DSM(Driver's Seat Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	HCM(Headlamp Control Module)																V																																		
BETA-TEST	MONDEO-2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	IPC(Instrument Panel Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	PAM(Parking Aid Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	PBM(Parking Brake Control Module)									V																																									
BETA-TEST	MONDEO-2.0L DIESEL	PDM(Passenger's Door Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	PSCM(Power Steering Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	RCM(Restraint Control Module)										V																																								
BETA-TEST	MONDEO-2.0L DIESEL	RFA(Remote Function Actuator)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	SASM(Steering Angle Sensor Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	SRM(Speech Recognition Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	TCM(Transmission Control Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	TRM(Trailer Module)																																																		
BETA-TEST	MONDEO-2.0L DIESEL	VDM(Vehicle Dynamic Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	SYSTEM SEARCH																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	PCM(PowerTrain Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	BCMii(Body Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	CCMii(Cruise Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	CMR(Camera Module Rear)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	DDM(Driver's Door Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	DSM(Driver's Seat Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	HCM(Headlamp Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	IPC(Instrument Panel Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	PAM(Parking Aid Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	PBM(Parking Brake Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	PDM(Passenger's Door Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	PSCM(Power Steering Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	RCM(Restraint Control Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	RFA(Remote Function Actuator)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	SRM(Speech Recognition Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	TCM(Transmission Control Module)																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	SCCM Module Installation	Enter the Fuel Injector Default Count Value	TPMS Drive the Vehicle	SOD-L Module Reset	SOD-R Module Reset	Configuration the yaw rate sensor	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	Ignition key code erase	Read the Sensor Cluster serial Number	Head Lamp Alignment	Injector Correction Factor	DCSM Module Installation	DDM Module Installation	IPC Module Installation	ABS Configuration Reset	BEM Module Installation	Steering Wheel Position Calibration	SAS Calibration	SAS Check	ABS reset and configuration	Gauge Test	Button Test	Illumination Test	IC Switch Test	ACM Calibration	Reset the oil change indicator	HIM Module Installation	PAM Module Installation	Steering Angle Sensor Calibration	Erase and Program keys	Parameter reset	Keyfob training	Exterior lighting	Climate control	Personality	Calibration	Audio configuration	Parameter reset(LPG)	Body type	Reset the Fuel Injector Learned Values-Cylinder 1	Reset the Fuel Injector Learned Values-Cylinder 2	Reset the Fuel Injector Learned Values-Cylinder 3	Reset the Fuel Injector Learned Values-Cylinder 4	Parameter Reset/Configuration BCMli
BETA-TEST	MONDEO-2.5L GASOLINE	TRM(Trailer Module)																																																		
BETA-TEST	MONDEO-2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	SYSTEM SEARCH																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	PCM(PowerTrain Control Module)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	ACM(Audio Control Module)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	CDP(Compact Disc Player)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	GDM(Generic Display Module)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	GEM(Generic Electronic Module)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	NAV(Navigation System)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	RCM(Restraint Control Module)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	RETM(Rear Entertainment Module)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																																																		
BETA-TEST	MONDEO-3.0L Duratec-ST	SRM(Speech Recognition Module)																																																		
BETA-TEST	F-150 5.4L	SYSTEM SEARCH																																																		
BETA-TEST	F-150 5.4L	PCM(PowerTrain Control Module)																																																		
BETA-TEST	F-150 5.4L	4X4(4x4 Control Module)																																																		
BETA-TEST	F-150 5.4L	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	F-150 5.4L	DSM(Driver Seat Module)																																																		
BETA-TEST	F-150 5.4L	EATC(Electronic Automatic Temperature Control)																																																		
BETA-TEST	F-150 5.4L	IC(Instrument Cluster)																																																		
BETA-TEST	F-150 5.4L	PAM(Parking Aid Module)																																																		
BETA-TEST	F-150 5.4L	RCM(Restraint Control Module)																																																		
BETA-TEST	F-150 5.4L	VSM(Vehicle Security Module)																																																		
BETA-TEST	F-150 5.4L	PATS(Passive Anti Theft System)																																																		
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	SYSTEM SEARCH																																																		
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PCM(PowerTrain Control Module)																																																		
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	ABS(Anti-Lock Brake System)																																																		
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	IC(Instrument Cluster)																																																		
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PAM(Parking Aid Module)																																																		
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	RCM(Restraint Control Module)																																																		
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	VSM(Vehicle Security Module)																																																		
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																		
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																		
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
Incode Calculator	~2010.05	All model																																															
ESCAPE	Up to 2004	SYSTEM SEARCH																																															
ESCAPE	Up to 2004	PCM(PowerTrain Control Module)																																															
ESCAPE	Up to 2004	Immobilizer																																															
ESCAPE	Up to 2004	ABS(Anti-Lock Brake System)																																															
ESCAPE	Up to 2004	RCM(Restraint Control Module)																																															
ESCAPE	Up to 2004	GEM(Generic Electronic Module)																																															
ESCAPE	From 2004	SYSTEM SEARCH																																															
ESCAPE	From 2004	PCM(PowerTrain Control Module)																																															
ESCAPE	From 2004	PATS(Passive anti theft system)																																															
ESCAPE	From 2004	ABS(Anti-Lock Brake System)																																															
ESCAPE	From 2004	ABS(Anti-Lock Brake System)																																															
ESCAPE	From 2004	RCM(Restraint Control Module)																																															
ESCAPE	From 2004	IC(Instrument Cluster)																																															
ESCAPE	From 2004	GEM(Generic Electronic Module)																																															
EXPLORER	2011 MY	3.5L TiCVT	SYSTEM SEARCH																																														
EXPLORER	2011 MY	3.5L TiCVT	PCM(Powertrain Control Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	ABS(Anti-Lock Brake System)																																														
EXPLORER	2011 MY	3.5L TiCVT	ACM(Audio Control Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	APIM(Accessory Protocol Interface Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	BCM(Body Control Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	ATCM(All Terrain Control Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	C-CM(Cruise Control Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	CLM(Column Lock Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	DCSM(Driver-Dual Climate Contol Seat Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	DSM(Driver Seat Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	DSP(Digital Signal Processing Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	FCIM(Front Controls Interface Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	FCDIM(Front Control/Display Interface Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	FLM(Front Lighting Control Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	GPSM(Global Positioning System Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	HUD(Head Up Display)																																														
EXPLORER	2011 MY	3.5L TiCVT	HVAC(Heating Ventilation Air Conditioning)																																														
EXPLORER	2011 MY	3.5L TiCVT	IPC(Instrument Panel Control Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	LTM(Liftgate/Trunk Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	OCSM(Occupant Classification System Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	PAM(Parking Aid Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	PSCM(Power Steering Control Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	RCM(Restraint Control Module)																																														
EXPLORER	2011 MY	3.5L TiCVT	RFA(Remote Function Actuator)																																														
EXPLORER	2011 MY	3.5L TiCVT	RLCM-A(Rear Lighting Control Module A)																																														
EXPLORER	2011 MY	3.5L TiCVT	SCCM(Streering Colume Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
EXPLORER	2011 MY	3.5L TiCVT	SOD-L(Side Obstacle Detection Control Module Left)																																															
EXPLORER	2011 MY	3.5L TiCVT	SOD-R(Side Obstacle Detection Control Module Right)																																															
EXPLORER	2011 MY	3.5L TiCVT	TPM(Tire Pressure Monitor)																																															
EXPLORER	2010 MY	4.6L	SYSTEM SEARCH																																															
EXPLORER	2010 MY	4.6L	PCM(Powertrain Control Module)																																															
EXPLORER	2010 MY	4.6L	TCM(Transmission Control Module)																																															
EXPLORER	2010 MY	4.6L	4X4(4x4 Control Module)																																															
EXPLORER	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																															
EXPLORER	2010 MY	4.6L	ACM(Audio Control Module)																																															
EXPLORER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																															
EXPLORER	2010 MY	4.6L	GPSM(Global Positioning System Module)																																															
EXPLORER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																															
EXPLORER	2010 MY	4.6L	DSM(Driver's Seat Module)																																															
EXPLORER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																															
EXPLORER	2010 MY	4.6L	IC(Instrument Cluster)																																															
EXPLORER	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																															
EXPLORER	2010 MY	4.6L	PAM(Parking Aid Module)																																															
EXPLORER	2010 MY	4.6L	PRB(Power Running Board)																																															
EXPLORER	2010 MY	4.6L	RCM(Restraint Control Module)																																															
EXPLORER	2010 MY	4.6L	RETM(Rear Entertainment Module)																																															
EXPLORER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																															
EXPLORER	2009 MY	4.6L	SYSTEM SEARCH																																															
EXPLORER	2009 MY	4.6L	PCM(Powertrain Control Module)																																															
EXPLORER	2009 MY	4.6L	TCM(Transmission Control Module)																																															
EXPLORER	2009 MY	4.6L	4X4(4x4 Control Module)																																															
EXPLORER	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																															
EXPLORER	2009 MY	4.6L	ACM(Audio Control Module)																																															
EXPLORER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																															
EXPLORER	2009 MY	4.6L	GPSM(Global Positioning System Module)																																															
EXPLORER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																															
EXPLORER	2009 MY	4.6L	DSM(Driver's Seat Module)																																															
EXPLORER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																															
EXPLORER	2009 MY	4.6L	IC(Instrument Cluster)																																															
EXPLORER	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																															
EXPLORER	2009 MY	4.6L	PAM(Parking Aid Module)																																															
EXPLORER	2009 MY	4.6L	PRB(Power Running Board)																																															
EXPLORER	2009 MY	4.6L	RCM(Restraint Control Module)																																															
EXPLORER	2009 MY	4.6L	RETM(Rear Entertainment Module)																																															
EXPLORER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																															
EXPLORER	2008 MY	4.6L	SYSTEM SEARCH																																															
EXPLORER	2008 MY	4.6L	PCM(Powertrain Control Module)																																															
EXPLORER	2008 MY	4.6L	TCM(Transmission Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
EXPLORER	2008 MY	4.6L	4X4(4x4 Control Module)																																														
EXPLORER	2008 MY	4.6L	ABS(Anti-Lock Brake System)																																														
EXPLORER	2008 MY	4.6L	ACM(Audio Control Module)																																														
EXPLORER	2008 MY	4.6L	DSM(Driver's Seat Module)																																														
EXPLORER	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																														
EXPLORER	2008 MY	4.6L	GEM(Generic Electronic Module)																																														
EXPLORER	2008 MY	4.6L	IC(Instrument Cluster)																																														
EXPLORER	2008 MY	4.6L	OCSM(Occupant Classification System Module)																																														
EXPLORER	2008 MY	4.6L	PAM(Parking Aid Module)																																														
EXPLORER	2008 MY	4.6L	PRB(Power Running Board)																																														
EXPLORER	2008 MY	4.6L	RCM(Restraint Control Module)																																														
EXPLORER	2008 MY	4.6L	RETM(Rear Entertainment Module)																																														
EXPLORER	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																														
EXPLORER	2007 MY	4.6L	SYSTEM SEARCH																																														
EXPLORER	2007 MY	4.6L	PCM(Powertrain Control Module)																																														
EXPLORER	2007 MY	4.6L	TCM(Transmission Control Module)																																														
EXPLORER	2007 MY	4.6L	4X4(4x4 Control Module)																																														
EXPLORER	2007 MY	4.6L	ABS(Anti-Lock Brake System)																																														
EXPLORER	2007 MY	4.6L	ACM(Audio Control Module)																																														
EXPLORER	2007 MY	4.6L	DSM(Driver's Seat Module)																																														
EXPLORER	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																														
EXPLORER	2007 MY	4.6L	GEM(Generic Electronic Module)																																														
EXPLORER	2007 MY	4.6L	IC(Instrument Cluster)																																														
EXPLORER	2007 MY	4.6L	OCSM(Occupant Classification System Module)																																														
EXPLORER	2007 MY	4.6L	PAM(Parking Aid Module)																																														
EXPLORER	2007 MY	4.6L	PRB(Power Running Board)																																														
EXPLORER	2007 MY	4.6L	RCM(Restraint Control Module)																																														
EXPLORER	2007 MY	4.6L	RETM(Rear Entertainment Module)																																														
EXPLORER	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																														
EXPLORER	2006 MY	4.6L	SYSTEM SEARCH																																														
EXPLORER	2006 MY	4.6L	PCM(Powertrain Control Module)																																														
EXPLORER	2006 MY	4.6L	TCM(Transmission Control Module)																																														
EXPLORER	2006 MY	4.6L	4X4(4x4 Control Module)																																														
EXPLORER	2006 MY	4.6L	ABS(Anti-Lock Brake System)																																														
EXPLORER	2006 MY	4.6L	ACM(Audio Control Module)																																														
EXPLORER	2006 MY	4.6L	DSM(Driver's Seat Module)																																														
EXPLORER	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																														
EXPLORER	2006 MY	4.6L	GEM(Generic Electronic Module)																																														
EXPLORER	2006 MY	4.6L	IC(Instrument Cluster)																																														
EXPLORER	2006 MY	4.6L	OCSM(Occupant Classification System Module)																																														
EXPLORER	2006 MY	4.6L	PAM(Parking Aid Module)																																														
EXPLORER	2006 MY	4.6L	PRB(Power Running Board)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
EXPLORER	2006 MY	4.6L	RCM(Restraint Control Module)																																														
EXPLORER	2006 MY	4.6L	RETM(Rear Entertainment Module)																																														
EXPLORER	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																														
EXPLORER	2000 MY	SYSTEM SEARCH																																															
EXPLORER	2000 MY	PCM(PowerTrain Control Module)																																															
EXPLORER	2000 MY	ABS(Anti-Lock Brake System)																																															
EXPLORER	2000 MY	RCM(Restraint Control Module)																																															
EXPLORER	2000 MY	RIM(Remote Immobilizer Module)																																															
EXPLORER	2000 MY	GEM(Generic Electronic Module)																																															
EXPLORER	2000 MY	PAM(Parking Aid Module)																																															
EXPLORER	1999 MY	SYSTEM SEARCH																																															
EXPLORER	1999 MY	PCM(PowerTrain Control Module)																																															
EXPLORER	1999 MY	ABS(Anti-Lock Brake System)																																															
EXPLORER	1999 MY	RCM(Restraint Control Module)																																															
EXPLORER	1999 MY	RIM(Remote Immobilizer Module)																																															
EXPLORER	1999 MY	PAM(Parking Aid Module)																																															
EXPLORER	1998 MY	SYSTEM SEARCH																																															
EXPLORER	1998 MY	PCM(PowerTrain Control Module)																																															
EXPLORER	1998 MY	ABS(Anti-Lock Brake System)																																															
EXPLORER	1998 MY	RCM(Restraint Control Module)																																															
EXPLORER	1998 MY	RIM(Remote Immobilizer Module)																																															
EXPLORER	1997 MY	SYSTEM SEARCH																																															
EXPLORER	1997 MY	PCM(PowerTrain Control Module)																																															
EXPLORER	1997 MY	ABS(Anti-Lock Brake System)																																															
EXPLORER	1997 MY	RCM(Restraint Control Module)																																															
EXPLORER	1997 MY	RIM(Remote Immobilizer Module)																																															
EXPLORER SPORT-TRAC	2010 MY	4.6L	SYSTEM SEARCH																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	PCM(Powertrain Control Module)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	TCM(Transmission Control Module)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	4X4(4x4 Control Module)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	ACM(Audio Control Module)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	GPSM(Global Positioning System Module)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	DSM(Driver's Seat Module)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	IC(Instrument Cluster)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	PAM(Parking Aid Module)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	PRB(Power Running Board)																																														
EXPLORER SPORT-TRAC	2010 MY	4.6L	RCM(Restraint Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
EXPLORER SPORT-TRAC	2010 MY	4.6L	RETM(Rear Entertainment Module)																																															
EXPLORER SPORT-TRAC	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	SYSTEM SEARCH																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	PCM(Powertrain Control Module)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	TCM(Transmission Control Module)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	4X4(4x4 Control Module)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	ACM(Audio Control Module)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	GPSM(Global Positioning System Module)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	DSM(Driver's Seat Module)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	IC(Instrument Cluster)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	PAM(Parking Aid Module)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	PRB(Power Running Board)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	RCM(Restraint Control Module)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	RETM(Rear Entertainment Module)																																															
EXPLORER SPORT-TRAC	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	SYSTEM SEARCH																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	PCM(Powertrain Control Module)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	TCM(Transmission Control Module)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	4X4(4x4 Control Module)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	ABS(Anti-Lock Brake System)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	ACM(Audio Control Module)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	DSM(Driver's Seat Module)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	GEM(Generic Electronic Module)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	IC(Instrument Cluster)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	OCSM(Occupant Classification System Module)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	PAM(Parking Aid Module)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	PRB(Power Running Board)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	RCM(Restraint Control Module)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	RETM(Rear Entertainment Module)																																															
EXPLORER SPORT-TRAC	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	SYSTEM SEARCH																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	PCM(Powertrain Control Module)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	TCM(Transmission Control Module)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	4X4(4x4 Control Module)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	ABS(Anti-Lock Brake System)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	ACM(Audio Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
EXPLORER SPORT-TRAC	2007 MY	4.6L	DSM(Driver's Seat Module)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	GEM(Generic Electronic Module)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	IC(Instrument Cluster)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	OCSM(Occupant Classification System Module)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	PAM(Parking Aid Module)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	PRB(Power Running Board)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	RCM(Restraint Control Module)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	RETM(Rear Entertainment Module)																																															
EXPLORER SPORT-TRAC	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	SYSTEM SEARCH																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	PCM(Powertrain Control Module)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	TCM(Transmission Control Module)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	4X4(4x4 Control Module)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	ABS(Anti-Lock Brake System)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	ACM(Audio Control Module)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	DSM(Driver's Seat Module)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	EATC(Electronic Automatic Temperature Control)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	GEM(Generic Electronic Module)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	IC(Instrument Cluster)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	OCSM(Occupant Classification System Module)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	PAM(Parking Aid Module)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	PRB(Power Running Board)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	RCM(Restraint Control Module)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	RETM(Rear Entertainment Module)																																															
EXPLORER SPORT-TRAC	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																															
ECOSPORT	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	BCM(Body Control Module)																																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	GPSM(Global Positioning System Module)																																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																															
ECOSPORT	1.5L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																															
ECOSPORT	1.5L	DURATEC VCT	SYSTEM SEARCH																																															
ECOSPORT	1.5L	DURATEC VCT	PCM(Powertrain Control Module)																																															
ECOSPORT	1.5L	DURATEC VCT	ABS(Anti-Lock Brake System)																																															
ECOSPORT	1.5L	DURATEC VCT	ACM(Audio Control Module)																																															
ECOSPORT	1.5L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																																															
ECOSPORT	1.5L	DURATEC VCT	BCMii(Body Control Module)																																															
ECOSPORT	1.5L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																																															
ECOSPORT	1.5L	DURATEC VCT	GPSM(Global Positioning System Module)																																															
ECOSPORT	1.5L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																															
ECOSPORT	1.5L	DURATEC VCT	IPC(Instrument Panel Control Module)																																															
ECOSPORT	1.5L	DURATEC VCT	PSCM(Power Steering Control Module)																																															
ECOSPORT	1.5L	DURATEC VCT	RCM(Restraint Control Module)																																															
ECOSPORT	1.5L	DURATEC VCT	RFA(Remote Function Actuator)																																															
ECOSPORT	1.5L	DURATEC VCT	TCM(Transmission Control Module)																																															
FIESTA	1.25L	DURATEC 16V	SYSTEM SEARCH																																															
FIESTA	1.25L	DURATEC 16V	PCM(PowerTrain Control Module)																																															
FIESTA	1.25L	DURATEC 16V	ABS(Anti-Lock Brake System)																																															
FIESTA	1.25L	DURATEC 16V	ACM(Audio Control Module)																																															
FIESTA	1.25L	DURATEC 16V	APIM(Accessory Protocol Interface Module)																																															
FIESTA	1.25L	DURATEC 16V	BCMii(Body Control Module)																																															
FIESTA	1.25L	DURATEC 16V	DDM(Driver's Door Module)																																															
FIESTA	1.25L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																																															
FIESTA	1.25L	DURATEC 16V	FDSM(Front Distance Sensing Module)																																															
FIESTA	1.25L	DURATEC 16V	GPSM(Global Positioning System Module)																																															
FIESTA	1.25L	DURATEC 16V	HVAC(Heating Ventilation Air Conditioning)																																															
FIESTA	1.25L	DURATEC 16V	IPC(Instrument Panel Control Module)																																															
FIESTA	1.25L	DURATEC 16V	PDM(Passenger's Door Module)																																															
FIESTA	1.25L	DURATEC 16V	PSCM(Power Steering Control Module)																																															
FIESTA	1.25L	DURATEC 16V	RCM(Restraint Control Module)																																															
FIESTA	1.25L	DURATEC 16V	RFA(Remote Function Actuator)																																															
FIESTA	1.4L GASOLINE	SYSTEM SEARCH																																																
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FIESTA	1.4L GASOLINE	PCM(PowerTrain Control Module)																																															
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)																																															
FIESTA	1.4L GASOLINE	TCM(Transmission Control Module)																																															
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																															
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																															
FIESTA	1.4L GASOLINE	ABS(Anti-Lock Brake System)																																															
FIESTA	1.4L GASOLINE	APIM(Accessory Protocol Interface Module)																																															
FIESTA	1.4L GASOLINE	PSCM(Power Steering Control Module)																																															
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)																																															
FIESTA	1.4L GASOLINE	RCM(Restraint Control Module)																																															
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)																																															
FIESTA	1.4L GASOLINE	IPC(Instrument Panel Control Module)																																															
FIESTA	1.4L GASOLINE	GEM(Generic Electronic Module)																																															
FIESTA	1.4L GASOLINE	BCMii(Body Control Module)																																															
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																															
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																															
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																															
FIESTA	1.4L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																															
FIESTA	1.4L GASOLINE	RFA(Remote Function Actuator)																																															
FIESTA	1.4L GASOLINE	SRM(Speech Recognition Module)																																															
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)																																															
FIESTA	1.4L GASOLINE	ACM(Audio Control Module)																																															
FIESTA	1.4L GASOLINE	DDM(Driver's Door Module)																																															
FIESTA	1.4L GASOLINE	FDSM(Front Distance Sensing Module)																																															
FIESTA	1.4L GASOLINE	FCDIM(Front Control/Display Interface Module)																																															
FIESTA	1.4L GASOLINE	GPSM(Global Positioning System Module)																																															
FIESTA	1.4L GASOLINE	PDM(Passenger's Door Module)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																														
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Retraint Control Module)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																															
FIESTA	1.4L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)																																															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Retraint Control Module)																																															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																															
FIESTA	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																															
FIESTA	1.5L	TiVCT	SYSTEM SEARCH																																															
FIESTA	1.5L	TiVCT	PCM(PowerTrain Control Module)																																															
FIESTA	1.5L	TiVCT	ABS(Anti-Lock Brake System)																																															
FIESTA	1.5L	TiVCT	ACM(Audio Control Module)																																															
FIESTA	1.5L	TiVCT	BCMii(Body Control Module)																																															
FIESTA	1.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																																															
FIESTA	1.5L	TiVCT	IPC(Instrument Panel Control Module)																																															
FIESTA	1.5L	TiVCT	PSCM(Power Steering Control Module)																																															
FIESTA	1.5L	TiVCT	RCM(Retraint Control Module)																																															
FIESTA	1.5L	TiVCT	RFA(Remote Function Actuator)																																															
FIESTA	1.5L	TiVCT	SRM(Speech Recognition Module)																																															
FIESTA	1.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																																															
FIESTA	1.5L	TiVCT	TCM(Transmission Control Module)																																															
FIESTA	1.6L GASOLINE	SYSTEM SEARCH																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																															
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																															
FIESTA	1.6L GASOLINE	PCM(PowerTrain Control Module)																																															
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)																																															
FIESTA	1.6L GASOLINE	TCM(Transmission Control Module)																																															
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																															
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																															
FIESTA	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																															
FIESTA	1.6L GASOLINE	PSCM(Power Steering Control Module)																																															
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)																																															
FIESTA	1.6L GASOLINE	RCM(Restraint Control Module)																																															
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																															
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																															
FIESTA	1.6L GASOLINE	IPC(Instrument Panel Control Module)																																															
FIESTA	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)																																															
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)																																															
FIESTA	1.6L GASOLINE	GEM(Generic Electronic Module)																																															
FIESTA	1.6L GASOLINE	BCMii(Body Control Module)																																															
FIESTA	1.6L GASOLINE	FCDIM(Front Control/Display Interface Module)																																															
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)																																															
FIESTA	1.6L GASOLINE	SRM(Speech Recognition Module)																																															
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)																																															
FIESTA	1.6L GASOLINE	ACM(Audio Control Module)																																															
FIESTA	1.6L ZETEC ROCAM	SYSTEM SEARCH																																															
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)																																															
FIESTA	1.6L ZETEC ROCAM	PCM(PowerTrain Control Module)																																															
FIESTA	1.6L ZETEC ROCAM	ABS(Anti-Lock Brake System)																																															
FIESTA	1.6L ZETEC ROCAM	IC(Instrument Cluster)																																															
FIESTA	1.6L ZETEC ROCAM	RCM(Restraint Control Module)																																															
FIESTA	1.6L ZETEC ROCAM	RKE(Remote Keyless Entry)																																															
FIESTA	1.6L ZETEC ROCAM	TCM(Transmission Control Module)																																															
FIESTA	1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																															
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																															
FIESTA	1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																															
FIESTA	1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																																															
FIESTA	1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																																															
FIESTA	1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																																															
FIESTA	2.0L GASOLINE	SYSTEM SEARCH																																															
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																															
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																															
FIESTA	2.0L GASOLINE	PCM(PowerTrain Control Module)																																															
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FIESTA	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																															
FIESTA	2.0L GASOLINE	ACM(Audio Control Module)																																															
FIESTA	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																															
FIESTA	2.0L GASOLINE	GEM(Generic Electronic Module)																																															
FIESTA	2.0L GASOLINE	IC(Instrument Cluster)																																															
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)																																															
FIESTA	2.0L GASOLINE	SRM(Speech Recognition Module)																																															
FIESTA	2.0L GASOLINE	RCM(Restraint Control Module)																																															
FIESTA	2.0L GASOLINE	PATS(Passive Anti Theft System)-BETA																																															
FIGO	1.4L DIESEL	SYSTEM SEARCH																																															
FIGO	1.4L DIESEL	PCM(Powertrain Control Module)																																															
FIGO	1.4L DIESEL	ABS(Anti-Lock Brake System)																																															
FIGO	1.4L DIESEL	IC(Instrument Cluster)																																															
FIGO	1.4L DIESEL	RCM(Restraint Control Module)																																															
FIGO	1.6L	DURATEC 16V	SYSTEM SEARCH																																														
FIGO	1.6L	DURATEC 16V	PCM(Powertrain Control Module)																																														
FIGO	1.6L	DURATEC 16V	ABS(Anti-Lock Brake System)																																														
FIGO	1.6L	DURATEC 16V	GEM(Generic Electronic Module)																																														
FIGO	1.6L	DURATEC 16V	IC(Instrument Cluster)																																														
FIGO	1.6L	DURATEC 16V	RCM(Restraint Control Module)																																														
FIGO	1.6L	DURATEC 16V	TCM(Transmission Control Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM(Front Distance Sensing Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																														
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																															
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																															
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																															
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																															
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																															
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																																															
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																																															
FOCUS	1.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																															
FOCUS	1.4L	DURATEC 16V	SYSTEM SEARCH																																															
FOCUS	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																																															
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																																															
FOCUS	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																																															
FOCUS	1.4L	DURATEC 16V	ACM(Audio Control Module)																																															
FOCUS	1.4L	DURATEC 16V	CDP(Compact Disc Player)																																															
FOCUS	1.4L	DURATEC 16V	D_DCU(Driver Door Control Unit)																																															
FOCUS	1.4L	DURATEC 16V	GDM(Generic Display Module)																																															
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																																															
FOCUS	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																																															
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)																																															
FOCUS	1.4L	DURATEC 16V	HCM(Headlamp Control Module)																																															
FOCUS	1.4L	DURATEC 16V	EATC(Electronic Automatic Temperature Control)																																															
FOCUS	1.4L	DURATEC 16V	FFH(Fuel Fired Coolant Heating Module)																																															
FOCUS	1.4L	DURATEC 16V	IC(Instrument Cluster)																																															
FOCUS	1.4L	DURATEC 16V	NAV(Navigation System)																																															
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)																																															
FOCUS	1.4L	DURATEC 16V	PAM(Parking Aid Module)																																															
FOCUS	1.4L	DURATEC 16V	PDM(Passenger's Door Module)																																															
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)																																															
FOCUS	1.4L	DURATEC 16V	RCM(Restraint Control Module)																																															
FOCUS	1.4L	DURATEC 16V	RKE(Remote Keyless Entry)																																															
FOCUS	1.4L	DURATEC 16V	CSM(Central Security Module)																																															
FOCUS	1.4L	DURATEC 16V	HEC(Hybrid Electrical Cluster)																																															
FOCUS	1.4L	DURATEC 16V	MC(Message Center)																																															
FOCUS	1.4L	DURATEC 16V	RETM(Rear Entertainment Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TCM(Transmission Control Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body control module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	CCMii(Cruise Control Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	DDM(Driver's Door Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	DDM(Driver's Door Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FCIM(Front Controls Interface Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FDSM(Front Distance Sensing Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	FCDIM(Front Control/Display Interface Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	GPSM(Global Positioning System Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	HCM(Headlamp Control Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	HVAC(Heating Ventilation Air Conditioning)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	IPM-A(Image Processing Module A)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	IPC(Instrument Panel Control Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PAM(Parking Aid Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PDM(Passenger's Door Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	PSCM(Power Steering Control Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	RCM(Restraint Control Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	RFA(Remote Function Actuator)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SASM(Steering Angle Sensor Module)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SOD-L(Side Obstacle Detection Control Module Left)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	SOD-R(Side Obstacle Detection Control Module Right)																																															
FOCUS	1.5L	Duratorq-Turbo Diesel Common Rail Injection Stg/VI	TRM(Trailer Module)																																															
FOCUS	1.6L GASOLINE	ZETEC SE	SYSTEM SEARCH																																															
FOCUS	1.6L GASOLINE	ZETEC SE	PCM(PowerTrain Control Module)																																															
FOCUS	1.6L GASOLINE	ZETEC SE	ABS(Anti-Lock Brake System)																																															
FOCUS	1.6L GASOLINE	ZETEC SE	EATC(Electronic Automatic Temperature Control)																																															
FOCUS	1.6L GASOLINE	ZETEC SE	GEM(Generic Electronic Module)																																															
FOCUS	1.6L GASOLINE	ZETEC SE	RCM(Restraint Control Module)																																															
FOCUS	1.6L GASOLINE	ZETEC SE	MC(Message Center)																																															
FOCUS	1.6L GASOLINE	DURATEC	SYSTEM SEARCH																																															
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)																																															
FOCUS	1.6L GASOLINE	DURATEC	PCM(PowerTrain Control Module)																																															
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)																																															
FOCUS	1.6L GASOLINE	DURATEC	ABS(Anti-Lock Brake System)																																															
FOCUS	1.6L GASOLINE	DURATEC	ACM(Audio Control Module)																																															
FOCUS	1.6L GASOLINE	DURATEC	CDP(Compact Disc Player)																																															
FOCUS	1.6L GASOLINE	DURATEC	D_DCU(Driver Door Control Unit)																																															
FOCUS	1.6L GASOLINE	DURATEC	GDM(Generic Display Module)																																															
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)																																															
FOCUS	1.6L GASOLINE	DURATEC	GEM(Generic Electronic Module)																																															
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)																																															
FOCUS	1.6L GASOLINE	DURATEC	HCM(Headlamp Control Module)																																															
FOCUS	1.6L GASOLINE	DURATEC	EATC(Electronic Automatic Temperature Control)																																															
FOCUS	1.6L GASOLINE	DURATEC	FFH(Fuel Fired Coolant Heating Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS	1.6L GASOLINE	DURATEC	IC(Instrument Cluster)																																														
FOCUS	1.6L GASOLINE	DURATEC	NAV(Navigation System)																																														
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)																																														
FOCUS	1.6L GASOLINE	DURATEC	PAM(Parking Aid Module)																																														
FOCUS	1.6L GASOLINE	DURATEC	PDM(Passenger's Door Module)																																														
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)																																														
FOCUS	1.6L GASOLINE	DURATEC	RCM(Restraint Control Module)																																														
FOCUS	1.6L GASOLINE	DURATEC	RKE(Remote Keyless Entry)																																														
FOCUS	1.6L GASOLINE	DURATEC	RL_DCU(Rear Left Door Control Unit)																																														
FOCUS	1.6L GASOLINE	DURATEC	RR_DCU(Rear Right Door Control Unit)																																														
FOCUS	1.6L GASOLINE	DURATEC	CSM(Central Security Module)																																														
FOCUS	1.6L GASOLINE	DURATEC	HEC(Hybrid Electrical Cluster)																																														
FOCUS	1.6L GASOLINE	DURATEC	MC(Message Center)																																														
FOCUS	1.6L GASOLINE	DURATEC	PATS(Passive Anti Theft System)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SYSTEM SEARCH																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PCM(PowerTrain Control Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TCM(Transmission Control Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ABS(Anti-Lock Brake System)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	ACM(Audio Control Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	APIM(Accessory Protocol Interface Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	BCMii(Body Control Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	CCMii(Cruise Control Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DDM(Driver's Door Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	DSP(Digital Signal Processing Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCIM(Front Controls Interface Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FDSM(Front Distance Sensing Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	FCDIM(Front Control/Display Interface Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HCM(Headlamp Control Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-A(Image Processing Module A)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPM-B(Image Processing Module B)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	IPC(Instrument Panel Control Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PAM(Parking Aid Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PDM(Passenger's Door Module)																																														
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PSCM(Power Steering Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)																																															
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RCM(Restraint Control Module)																																															
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	RFA(Remote Function Actuator)																																															
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SASM(Steering Angle Sensor Module)																																															
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SRM(Speech Recognition Module)																																															
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																																															
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																																															
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	TRM(Trailer Module)																																															
FOCUS	1.6L GASOLINE	2011 ~ DURATEC VCT	PATS(Passive Anti Theft System)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GDM(Generic Display Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	NAV(Navigation System)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Condtioning)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(PowerTrain Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Condtioning)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)																																															
FOCUS	1.6L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CMR(Camera Module Rear)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CDP(Compact Disc Player)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPB(Electronic Parking Brake)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	EPS(Electronic Power Steering)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GDM(Generic Display Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	GEM(Generic Electronic Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HCM(Headlamp Control Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	IC(Instrument Cluster)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	NAV(Navigation System)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PDM(Passenger's Door Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RETM(Rear Entertainment Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	RKE(Remote Keyless Entry)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	CSM(Central Security Module)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	MC(Message Center)																																															
FOCUS	1.8L GASOLINE	DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SYSTEM SEARCH																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PCM(PowerTrain Control Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	TCM(Transmission Control Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	ACM(Audio Control Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CMR(Camera Module Rear)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CDP(Compact Disc Player)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	CSM(Central Security Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPB(Electronic Parking Brake)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	EPS(Electronic Power Steering)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GDM(Generic Display Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	GEM(Generic Electronic Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HEC(Hybrid Electrical Cluster)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	HCM(Headlamp Control Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	IC(Instrument Cluster)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	MC(Message Center)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	NAV(Navigation System)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PAM(Parking Aid Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PDM(Passenger's Door Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RCM(Restraint Control Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RETM(Rear Entertainment Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	RKE(Remote Keyless Entry)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	SRM(Speech Recognition Module)																																															
FOCUS	2.0L GASOLINE	~ 2009 DURATEC-HE-I4	PATS(Passive Anti Theft System)-BETA																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SYSTEM SEARCH																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PCM(PowerTrain Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TCM(Transmission Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ABS(Anti-Lock Brake System)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	ACM(Audio Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	AHCM(Auxiliary Heater Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	APIM(Accessory Protocol Interface Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	BCMii(Body Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	CCMii(Cruise Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DDM(Driver's Door Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	DSP(Digital Signal Processing Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCIM(Front Controls Interface Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FDSM(Front Distance Sensing Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	FCDIM(Front Control/Display Interface Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HCM(Headlamp Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-A(Image Processing Module A)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPM-B(Image Processing Module B)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	IPC(Instrument Panel Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PAM(Parking Aid Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PDM(Passenger's Door Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PSCM(Power Steering Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RCM(Restraint Control Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	RFA(Remote Function Actuator)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SASM(Steering Angle Sensor Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SRM(Speech Recognition Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	TRM(Trailer Module)																																															
FOCUS	2.0L GASOLINE	Gasoline Direct Injection	PATS(Passive Anti Theft System)																																															
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	SYSTEM SEARCH																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PCM(PowerTrain Control Module)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	TCM(Transmission Control Module)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ACM(Audio Control Module)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ABS(Anti-Lock Brake System)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CDP(Compact Disc Player)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	CMR(Camera Module Rear)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	D_DCU(Driver Door Control Unit)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	ETC(Electronic Automatic Temperature Control)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	EPS(Electronic Power Steering)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FACM(Fuel Additive Control Module)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	FFH(Fuel Fired Coolant Heating Module)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	GEM(Generic Electronic Module)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	HCM(Headlamp Control Module)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	IC(Instrument Cluster)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PDM(Passenger's Door Module)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	PAM(Parking Aid Module)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RCM(Restraint Control Module)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RETM(Rear Entertainment Module)																																														
FOCUS	2.0L	Duratorq-Turbo Diesel Common Rail Injection	~2010	RKE(Remote Keyless Entry)																																														
FOCUS	2.5L GASOLINE	SYSTEM SEARCH																																																
FOCUS	2.5L GASOLINE	PCM(PowerTrain Control Module)																																																
FOCUS	2.5L GASOLINE	TCM(Transmission Control Module)																																																
FOCUS	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																																
FOCUS	2.5L GASOLINE	EPS(Electronic Power Steering)																																																
FOCUS	2.5L GASOLINE	RCM(Restraint Control Module)																																																
FOCUS	2.5L GASOLINE	GEM(Generic Electronic Module)																																																
FOCUS	2.5L GASOLINE	IC(Instrument Cluster)																																																
FOCUS	2.5L GASOLINE	DDM(Driver's Door Module)																																																
FOCUS	2.5L GASOLINE	PDM(Passenger's Door Module)																																																
FOCUS	2.5L GASOLINE	MC(Message Center)																																																
FOCUS	2.5L GASOLINE	ACM(Audio Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS C-MAX	1.6L DIESEL	SYSTEM SEARCH																																															
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	PCM(PowerTrain Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)																																															
FOCUS C-MAX	1.6L DIESEL	ABS(Anti-Lock Brake System)																																															
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	ACM(Audio Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	CDP(Compact Disc Player)																																															
FOCUS C-MAX	1.6L DIESEL	CMR(Camera Module Rear)																																															
FOCUS C-MAX	1.6L DIESEL	D_DCU(Driver Door Control Unit)																																															
FOCUS C-MAX	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)																																															
FOCUS C-MAX	1.6L DIESEL	EPS(Electronic Power Steering)																																															
FOCUS C-MAX	1.6L DIESEL	FACM(Fuel Additive Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																															
FOCUS C-MAX	1.6L DIESEL	GEM(Generic Electronic Module)																																															
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	HCM(Headlamp Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	IC(Instrument Cluster)																																															
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)																																															
FOCUS C-MAX	1.6L DIESEL	PAM(Parking Aid Module)																																															
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)																																															
FOCUS C-MAX	1.6L DIESEL	PDM(Passenger's Door Module)																																															
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	RCM(Restraint Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	RETM(Rear Entertainment Module)																																															
FOCUS C-MAX	1.6L DIESEL	RKE(Remote Keyless Entry)																																															
FOCUS C-MAX	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	BCMii(Body Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	DDM(Driver's Door Module)																																															
FOCUS C-MAX	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)																																															
FOCUS C-MAX	1.6L DIESEL	HVAC(Heating Ventilation Air Condtioning)																																															
FOCUS C-MAX	1.6L DIESEL	IPM-A(Image Processing Module A)																																															
FOCUS C-MAX	1.6L DIESEL	IPM-B(Image Processing Module B)																																															
FOCUS C-MAX	1.6L DIESEL	IPC(Instrument Panel Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	PSCM(Power Steering Control Module)																																															
FOCUS C-MAX	1.6L DIESEL	RFA(Remote Function Actuator)																																															
FOCUS C-MAX	1.6L DIESEL	RGTM(Rear Gate/Trunk Module)																																															
FOCUS C-MAX	1.6L DIESEL	SASM(Steering Angle Sensor Module)																																															
FOCUS C-MAX	1.6L DIESEL	SRM(Speech Recognition Module)																																															
FOCUS C-MAX	1.6L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																															
FOCUS C-MAX	1.6L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																															
FOCUS C-MAX	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS C-MAX	1.6L GASOLINE	SYSTEM SEARCH																																															
FOCUS C-MAX	1.6L GASOLINE	PCM(PowerTrain Control Module)																																															
FOCUS C-MAX	1.6L GASOLINE	ABS(Anti-Lock Brake System)																																															
FOCUS C-MAX	1.6L GASOLINE	ACM(Audio Control Module)																																															
FOCUS C-MAX	1.6L GASOLINE	CDP(Compact Disc Player)																																															
FOCUS C-MAX	1.6L GASOLINE	CMR(Camera Module Rear)																																															
FOCUS C-MAX	1.6L GASOLINE	D_DCU(Driver Door Control Unit)																																															
FOCUS C-MAX	1.6L GASOLINE	EATC(Electronic Automatic Temperature Control)																																															
FOCUS C-MAX	1.6L GASOLINE	EPS(Electronic Power Steering)																																															
FOCUS C-MAX	1.6L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																															
FOCUS C-MAX	1.6L GASOLINE	GEM(Generic Electronic Module)																																															
FOCUS C-MAX	1.6L GASOLINE	HCM(Headlamp Control Module)																																															
FOCUS C-MAX	1.6L GASOLINE	IC(Instrument Cluster)																																															
FOCUS C-MAX	1.6L GASOLINE	PAM(Parking Aid Module)																																															
FOCUS C-MAX	1.6L GASOLINE	PDM(Passenger's Door Module)																																															
FOCUS C-MAX	1.6L GASOLINE	RCM(Restraint Control Module)																																															
FOCUS C-MAX	1.6L GASOLINE	RETM(Rear Entertainment Module)																																															
FOCUS C-MAX	1.6L GASOLINE	RKE(Remote Keyless Entry)																																															
FOCUS C-MAX	1.6L GASOLINE	GDM(Generic Display Module)																																															
FOCUS C-MAX	1.6L GASOLINE	NAV(Navigation System)																																															
FOCUS C-MAX	1.6L GASOLINE	RL_DCU(Rear Left Door Control Unit)																																															
FOCUS C-MAX	1.6L GASOLINE	RR_DCU(Rear Right Door Control Unit)																																															
FOCUS C-MAX	1.6L GASOLINE	SRM(Speech Recognition Module)																																															
FOCUS C-MAX	1.6L GASOLINE	TCM(Transmission Control Module)																																															
FOCUS C-MAX	1.8L GASOLINE	SYSTEM SEARCH																																															
FOCUS C-MAX	1.8L GASOLINE	PCM(PowerTrain Control Module)																																															
FOCUS C-MAX	1.8L GASOLINE	ABS(Anti-Lock Brake System)																																															
FOCUS C-MAX	1.8L GASOLINE	ACM(Audio Control Module)																																															
FOCUS C-MAX	1.8L GASOLINE	CMR(Camera Module Rear)																																															
FOCUS C-MAX	1.8L GASOLINE	CDP(Compact Disc Player)																																															
FOCUS C-MAX	1.8L GASOLINE	D_DCU(Driver Door Control Unit)																																															
FOCUS C-MAX	1.8L GASOLINE	EATC(Electronic Automatic Temperature Control)																																															
FOCUS C-MAX	1.8L GASOLINE	EPB(Electronic Parking Brake)																																															
FOCUS C-MAX	1.8L GASOLINE	EPS(Electronic Power Steering)																																															
FOCUS C-MAX	1.8L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																															
FOCUS C-MAX	1.8L GASOLINE	GDM(Generic Display Module)																																															
FOCUS C-MAX	1.8L GASOLINE	GEM(Generic Electronic Module)																																															
FOCUS C-MAX	1.8L GASOLINE	HCM(Headlamp Control Module)																																															
FOCUS C-MAX	1.8L GASOLINE	IC(Instrument Cluster)																																															
FOCUS C-MAX	1.8L GASOLINE	NAV(Navigation System)																																															
FOCUS C-MAX	1.8L GASOLINE	PAM(Parking Aid Module)																																															
FOCUS C-MAX	1.8L GASOLINE	PDM(Passenger's Door Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS C-MAX	1.8L GASOLINE	RCM(Restraint Control Module)																																															
FOCUS C-MAX	1.8L GASOLINE	RETM(Rear Entertainment Module)																																															
FOCUS C-MAX	1.8L GASOLINE	RKE(Remote Keyless Entry)																																															
FOCUS C-MAX	1.8L GASOLINE	SRM(Speech Recognition Module)																																															
FOCUS C-MAX	2.0L DIESEL	SYSTEM SEARCH																																															
FOCUS C-MAX	2.0L DIESEL	PCM(PowerTrain Control Module)																																															
FOCUS C-MAX	2.0L DIESEL	ABS(Anti-Lock Brake System)																																															
FOCUS C-MAX	2.0L DIESEL	ACM(Audio Control Module)																																															
FOCUS C-MAX	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																															
FOCUS C-MAX	2.0L DIESEL	BCMii(Body Control Module)																																															
FOCUS C-MAX	2.0L DIESEL	DDM(Driver's Door Module)																																															
FOCUS C-MAX	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																																															
FOCUS C-MAX	2.0L DIESEL	HCM(Headlamp Control Module)																																															
FOCUS C-MAX	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																															
FOCUS C-MAX	2.0L DIESEL	IPM-A(Image Processing Module A)																																															
FOCUS C-MAX	2.0L DIESEL	IPM-B(Image Processing Module B)																																															
FOCUS C-MAX	2.0L DIESEL	IPC(Instrument Panel Control Module)																																															
FOCUS C-MAX	2.0L DIESEL	PAM(Parking Aid Module)																																															
FOCUS C-MAX	2.0L DIESEL	PDM(Passenger's Door Module)																																															
FOCUS C-MAX	2.0L DIESEL	PSCM(Power Steering Control Module)																																															
FOCUS C-MAX	2.0L DIESEL	RCM(Restraint Control Module)																																															
FOCUS C-MAX	2.0L DIESEL	RFA(Remote Function Actuator)																																															
FOCUS C-MAX	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																															
FOCUS C-MAX	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																															
FOCUS C-MAX	2.0L DIESEL	SRM(Speech Recognition Module)																																															
FOCUS C-MAX	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																															
FOCUS C-MAX	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																															
FOCUS C-MAX	2.0L GASOLINE	SYSTEM SEARCH																																															
FOCUS C-MAX	2.0L GASOLINE	PCM(PowerTrain Control Module)																																															
FOCUS C-MAX	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																															
FOCUS C-MAX	2.0L GASOLINE	ACM(Audio Control Module)																																															
FOCUS C-MAX	2.0L GASOLINE	CDP(Compact Disc Player)																																															
FOCUS C-MAX	2.0L GASOLINE	CMR(Camera Module Rear)																																															
FOCUS C-MAX	2.0L GASOLINE	D_DCU(Driver Door Control Unit)																																															
FOCUS C-MAX	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																															
FOCUS C-MAX	2.0L GASOLINE	EPB(Electronic Parking Brake)																																															
FOCUS C-MAX	2.0L GASOLINE	EPS(Electronic Power Steering)																																															
FOCUS C-MAX	2.0L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																															
FOCUS C-MAX	2.0L GASOLINE	GDM(Generic Display Module)																																															
FOCUS C-MAX	2.0L GASOLINE	GEM(Generic Electronic Module)																																															
FOCUS C-MAX	2.0L GASOLINE	HCM(Headlamp Control Module)																																															
FOCUS C-MAX	2.0L GASOLINE	IC(Instrument Cluster)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
FOCUS C-MAX	2.0L GASOLINE	NAV(Navigation System)																																															
FOCUS C-MAX	2.0L GASOLINE	PAM(Parking Aid Module)																																															
FOCUS C-MAX	2.0L GASOLINE	PDM(Passenger's Door Module)																																															
FOCUS C-MAX	2.0L GASOLINE	RCM(Restraint Control Module)																																															
FOCUS C-MAX	2.0L GASOLINE	RETM(Rear Entertainment Module)																																															
FOCUS C-MAX	2.0L GASOLINE	RKE(Remote Keyless Entry)																																															
FOCUS C-MAX	2.0L GASOLINE	SRM(Speech Recognition Module)																																															
FUSION	1.4L DIESEL	SYSTEM SEARCH																																															
FUSION	1.4L DIESEL	PCM(PowerTrain Control Module)																																															
FUSION	1.4L DIESEL	TCM(Transmission Control Module)																																															
FUSION	1.4L DIESEL	ABS(Anti-Lock Brake System)																																															
FUSION	1.4L DIESEL	IC(Instrument Cluster)																																															
FUSION	1.4L DIESEL	ACM(Audio Control Module)																																															
FUSION	1.4L DIESEL	EATC(Electronic Automatic Temperature Control)																																															
FUSION	1.4L DIESEL	GEM(Generic Electronic Module)																																															
FUSION	1.4L DIESEL	SRM(Speech Recognition Module)																																															
FUSION	1.4L DIESEL	RCM(Restraint Control Module)																																															
FUSION	1.4L DIESEL	PATS(Passive Anti Theft System)-BETA																																															
FUSION	1.6L DIESEL	SYSTEM SEARCH																																															
FUSION	1.6L DIESEL	PCM(PowerTrain Control Module)																																															
FUSION	1.6L DIESEL	TCM(Transmission Control Module)																																															
FUSION	1.6L DIESEL	ABS(Anti-Lock Brake System)																																															
FUSION	1.6L DIESEL	IC(Instrument Cluster)																																															
FUSION	1.6L DIESEL	ACM(Audio Control Module)																																															
FUSION	1.6L DIESEL	EATC(Electronic Automatic Temperature Control)																																															
FUSION	1.6L DIESEL	GEM(Generic Electronic Module)																																															
FUSION	1.6L DIESEL	SRM(Speech Recognition Module)																																															
FUSION	1.6L DIESEL	RCM(Restraint Control Module)																																															
FUSION	1.6L DIESEL	PATS(Passive Anti Theft System)-BETA																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															
GALAXY S-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																															
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
GALAXY S-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															
GALAXY S-MAX	2.0L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																															
GALAXY S-MAX	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TCM(Transmission Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CDP(Compact Disc Player)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	CMR(Camera Module Rear)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DABM(Digital Audio Broadcast Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver's Seat Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	HVAC(Heating Ventilation Air Conditioning)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	NAV(Navigation System)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PBM(Parking Brake Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RFA(Remote Function Actuator)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	RHVAC(Rear Heating Ventilation Air Conditioning)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SASM(Steering Angle Sensor Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SRM(Speech Recognition Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module - Left)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module - Right)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																															
GALAXY S-MAX	2.2L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																																															
F150	3.5L(BETA)	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																																															
F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																																															
F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																																															
F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																																															
F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																																															
F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																																															
F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																																															
F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																																															
F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																																															
F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																																															
F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																																															
F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																																															
F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																																															
F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																																															
F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																																															
F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																																															
F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																																															
F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																																															
F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																																															
F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																																															
F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																																															
F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																																															
F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																																															
F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																																															
F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																																													
F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																																													
F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																																													
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																																													
F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																																													
F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																																													
F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																																													
F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																																													
F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																																													
F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																																													
F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																													
F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																																													
F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																																													
F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																																													
F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																																													
F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																																													
F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																																													
F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																																													
F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																																													
F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																																													
F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																																													
F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																																													
F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																																													
F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																																													
F150	4.6L(BETA)	3V	SYSTEM SEARCH																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																																														
F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																																														
F150	4.6L(BETA)	3V	ACM(Audio Control Module)																																														
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																																														
F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																																														
F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																																														
F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																																														
F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																																														
F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																																														
F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																																														
F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																														
F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																																														
F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																																														
F150	4.6L(BETA)	3V	IC(Instrument Cluster)																																														
F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																																														
F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																																														
F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																																														
F150	4.6L(BETA)	3V	PRB(Power Running Board)																																														
F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																																														
F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																																														
F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																																														
F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																																														
F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																																														
F150	5.0L	TiVCT	SYSTEM SEARCH																																														
F150	5.0L	TiVCT	PCM(Powertrain Control Module)																																														
F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																																														
F150	5.0L	TiVCT	ACM(Audio Control Module)																																														
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																																														
F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																																														
F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																																														
F150	5.0L	TiVCT	DSM(Driver's Seat Module)																																														
F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																																														
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																														
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																														
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																														
F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																																														
F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																																														
F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																																														
F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																														
F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																																														
F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																																														
F150	5.0L	TiVCT	IC(Instrument Cluster)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																																														
F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																																														
F150	5.0L	TiVCT	PAM(Parking Aid Module)																																														
F150	5.0L	TiVCT	PAM(Parking Aid Module)																																														
F150	5.0L	TiVCT	PRB(Power Running Board)																																														
F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																																														
F150	5.0L	TiVCT	RCM(Restraint Control Module)																																														
F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																																														
F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																																														
F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																																														
F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																																														
F150	5.0L	TiVCT	TCM(Transmission Control Module)																																														
F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																																														
F150	5.4L	3V	2009 ~	SYSTEM SEARCH																																													
F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																																													
F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																																													
F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																																													
F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																																													
F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																																													
F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																																													
F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																																													
F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																																													
F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																																													
F150	5.4L	3V	2009 ~	GEMS/JB(Generic Electronic Module/Smart Junction Box)																																													
F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																																													
F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																																													
F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																																													
F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																																													
F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																																													
F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																																													
F150	5.4L	3V	2009 ~	PRB(Power Running Board)																																													
F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																																													
F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																																													
F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																																													
F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																																													
F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																																													
F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																																													
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																																													
F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																																													
F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																																													
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																													
F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																																													
F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																																													
F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																																													
F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																																													
F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																													
F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																																													
F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																																													
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																																													
F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																																													
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																																													
F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																																													
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																																													
F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																																													
F150	6.2L(BETA)	2V	SYSTEM SEARCH																																														
F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																																														
F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																																														
F150	6.2L(BETA)	2V	ACM(Audio Control Module)																																														
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																																														
F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																																														
F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																																														
F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																																														
F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																																														
F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																																														
F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																														
F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																																														
F150	6.2L(BETA)	2V	IC(Instrument Cluster)																																														
F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																																														
F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																																														
F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																																														
F150	6.2L(BETA)	2V	PRB(Power Running Board)																																														
F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																																														
F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																																														
F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																																														
F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																																														
F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																																														
F150	Other	2004 ~ 2008	SYSTEM SEARCH																																														
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																																														
F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																																														
F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																																														
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																																														
F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																																														
F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																																														
F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																																														
F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																																														
F150	Other	2004 ~ 2008	IC(Instrument Cluster)																																														
F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																																														
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																																														
F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																																														
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																																														
F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																																														
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																																														
F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																																														
F250	7.3L	SYSTEM SEARCH																																															
F250	7.3L	PCM(PowerTrain Control Module)																																															
F250	7.3L	ABS(Anti-Lock Brake System)																																															
F250	7.3L	ECS(Electronic Crash Sensor)																																															
F250	7.3L	GEM(Generic Electronic Module)																																															
F250	6.2L	SYSTEM SEARCH																																															
F250	6.2L	PCM(Powertrain Control Module)																																															
F250	6.2L	ABS(Anti-Lock Brake System)																																															
F250	6.2L	ACM(Audio Control Module)																																															
F250	6.2L	APIM(Accessory Protocol Interface Module)																																															
F250	6.2L	BCMii(Body Control Module)																																															
F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																																															
F250	6.2L	DSM(Driver Seat Module)																																															
F250	6.2L	GPSM(Global Positioning System Module)																																															
F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																																															
F250	6.2L	IPC(Instrument Panel Control Module)																																															
F250	6.2L	PAM(Parking Aid Module)																																															
F250	6.2L	RCM(Restraint Control Module)																																															
F250	6.2L	SCCM(Streering Colume Control Module)																																															
F250	6.2L	TBC(Trailer Brake Control Module)																																															
F250	6.2L	TCCM(Transfer Case Control Module)																																															
F250	6.2L	TPM(Tire Pressure Monitor)																																															
F250	6.0L Diesel	SYSTEM SEARCH																																															
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																															
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																															
F250	6.0L Diesel	PCM(PowerTrain Control Module)																																															
F250	6.0L Diesel	ABS(Anti-Lock Brake System)																																															
F250	6.0L Diesel	GEM(Generic Electronic Module)																																															
F250	6.0L Diesel	HEC(Hybrid Electrical Cluster)																																															
F250	6.0L Diesel	OTC(Overhead Trip Computer)																																															
F250	6.0L Diesel	PAM(Parking Aid Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F250	6.0L Diesel	PATS(Passive Anti Theft System)																																															
F250	6.0L Diesel	RCM(Restraint Control Module)																																															
F250	6.0L Diesel	TCM(Transmission Control Module)																																															
F250	6.0L Diesel	TCM(Transmission Control Module)																																															
F250	6.0L Diesel	TCM(Transmission Control Module)																																															
F250	6.0L Diesel	VSM(Vehicle Security Module)																																															
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																																													
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																																													
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																														
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																																														
IKON	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																																														
KA	KA	SYSTEM SEARCH																																															
KA	KA	PCM(PowerTrain Control Module)																																															
KA	KA	ABS(Anti-Lock Brake System)																																															
KA	KA	RCM(Restraint Control Module)																																															
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																														
KUGA	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																														
KUGA	2.0L DIESEL	SYSTEM SEARCH																																															
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)																																															
KUGA	2.0L DIESEL	PCM(PowerTrain Control Module)																																															
KUGA	2.0L DIESEL	TCM(Transmission Control Module)																																															
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)																																															
KUGA	2.0L DIESEL	ABS(Anti-Lock Brake System)																																															
KUGA	2.0L DIESEL	ACM(Audio Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
KUGA	2.0L DIESEL	ACM(Audio Control Module)																																															
KUGA	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																															
KUGA	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																																															
KUGA	2.0L DIESEL	AWD(All Wheel Drive Module)																																															
KUGA	2.0L DIESEL	BCMii(Body Control Module)																																															
KUGA	2.0L DIESEL	CCMii(Cruise Control Module)																																															
KUGA	2.0L DIESEL	CMR(Camera Module Rear)																																															
KUGA	2.0L DIESEL	D_DCU(Driver Door Control Unit)																																															
KUGA	2.0L DIESEL	DDM(Driver's Door Module)																																															
KUGA	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																															
KUGA	2.0L DIESEL	EPS(Electronic Power Steering)																																															
KUGA	2.0L DIESEL	FDSM(Front Distance Sensing Module)																																															
KUGA	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																																															
KUGA	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																															
KUGA	2.0L DIESEL	GEM(Generic Electronic Module)																																															
KUGA	2.0L DIESEL	GPSM(Global Positioning System Module)																																															
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)																																															
KUGA	2.0L DIESEL	HCM(Headlamp Control Module)																																															
KUGA	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																															
KUGA	2.0L DIESEL	IPM-A(Image Processing Module A)																																															
KUGA	2.0L DIESEL	IPM-B(Image Processing Module B)																																															
KUGA	2.0L DIESEL	IPC(Instrument Panel Control Module)																																															
KUGA	2.0L DIESEL	IC(Instrument Cluster)																																															
KUGA	2.0L DIESEL	PAM(Parking Aid Module)																																															
KUGA	2.0L DIESEL	PAM(Parking Aid Module)																																															
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)																																															
KUGA	2.0L DIESEL	PDM(Passenger's Door Module)																																															
KUGA	2.0L DIESEL	PSCM(Power Steering Control Module)																																															
KUGA	2.0L DIESEL	RCM(Restraint Control Module)																																															
KUGA	2.0L DIESEL	RCM(Restraint Control Module)																																															
KUGA	2.0L DIESEL	RFA(Remote Function Actuator)																																															
KUGA	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																															
KUGA	2.0L DIESEL	RETM(Rear Entertainment Module)																																															
KUGA	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																															
KUGA	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																															
KUGA	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																															
KUGA	2.0L DIESEL	SRM(Speech Recognition Module)																																															
KUGA	2.0L DIESEL	TRM(Trailer Module)																																															
KUGA	2.5L GASOLINE	SYSTEM SEARCH																																															
KUGA	2.5L GASOLINE	PCM(PowerTrain Control Module)																																															
KUGA	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																															
KUGA	2.5L GASOLINE	ACM(Audio Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
KUGA	2.5L GASOLINE	AWD(All Wheel Drive Module)																																															
KUGA	2.5L GASOLINE	CMR(Camera Module Rear)																																															
KUGA	2.5L GASOLINE	D_DCU(Driver Door Control Unit)																																															
KUGA	2.5L GASOLINE	EATC(Electronic Automatic Temperature Control)																																															
KUGA	2.5L GASOLINE	EPS(Electronic Power Steering)																																															
KUGA	2.5L GASOLINE	FFH(Fuel Fired Coolant Heating Module)																																															
KUGA	2.5L GASOLINE	GEM(Generic Electronic Module)																																															
KUGA	2.5L GASOLINE	HCM(Headlamp Control Module)																																															
KUGA	2.5L GASOLINE	IC(Instrument Cluster)																																															
KUGA	2.5L GASOLINE	PAM(Parking Aid Module)																																															
KUGA	2.5L GASOLINE	PDM(Passenger's Door Module)																																															
KUGA	2.5L GASOLINE	RCM(Restraint Control Module)																																															
KUGA	2.5L GASOLINE	RETM(Rear Entertainment Module)																																															
KUGA	2.5L GASOLINE	RKE(Remote Keyless Entry)																																															
KUGA	2.5L GASOLINE	SRM(Speech Recognition Module)																																															
KUGA	2.5L GASOLINE	TCM(Transmission Control Module)																																															
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																													
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																														
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SDD-R(Side Obstacle Detection Control Module - Right)																																													
MONDEO	2013~	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SYSTEM SEARCH																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PCM(Powertrain Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ABS(Anti-Lock Brake System)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	ACM(Audio Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	AHCM(Auxiliary Heater Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	APIM(Accessory Protocol Interface Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	BCMii(Body Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	CCMii(Cruise Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DCDC(DC to DC Convertal Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DDM(Driver's Door Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSM(Driver Seat Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	DSP(Digital Signal Processing Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCIM(Front Controls Interface Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FDSM(Front Distance Sensing Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	FCDIM(Front Control/Display Interface Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GPSM(Global Positioning System Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	GWM(Gateway Module A)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HCM(Headlamp Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HSWM(Heated Steering Wheel Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	HUD(Head Up Display)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPM-A(Image Processing Module A)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	IPC(Instrument Panel Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PAM(Parking Aid Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PDM(Passenger's Door Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	PSCM(Power Steering Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RACM(Rear Audio Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RCM(Restraint Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RGTM(Rear Gate/Trunk Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	RTM(Radio Transceiver Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCCM(Streering Colume Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-E(Seat Control Module E)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-G(Seat Control Module G)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SCM-H(Seat Control Module H)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SDD-L(Side Obstacle Detection Control Module Left)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	SDD-R(Side Obstacle Detection Control Module Right)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	TRM(Trailer Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgVI	VDM(Vehicle Dynamic Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SYSTEM SEARCH																																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PCM(Powertrain Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ABS(Anti-Lock Brake System)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	ACM(Audio Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	AHCM(Auxiliary Heater Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	APIM(Accessory Protocol Interface Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	BCMii(Body Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	CCMii(Cruise Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DCDC(DC to DC Convertal Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DDM(Driver's Door Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSM(Driver Seat Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	DSP(Digital Signal Processing Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCIM(Front Controls Interface Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FDSM(Front Distance Sensing Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	FCDIM(Front Control/Display Interface Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GPSM(Global Positioning System Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	GWM(Gateway Module A)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HCM(Headlamp Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HSWM(Heated Steering Wheel Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	HUD(Head Up Display)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPM-A(Image Processing Module A)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	IPC(Instrument Panel Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PAM(Parking Aid Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PDM(Passenger's Door Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	PSCM(Power Steering Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RACM(Rear Audio Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RCM(Restraint Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RGTM(Rear Gate/Trunk Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	RTM(Radio Transceiver Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCCM(Streering Colume Control Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-E(Seat Control Module E)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-G(Seat Control Module G)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SCM-H(Seat Control Module H)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-L(Side Obstacle Detection Control Module Left)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	SOD-R(Side Obstacle Detection Control Module Right)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	TRM(Trailer Module)																																													
MONDEO	2013~	2.0L	Duratorq-Turbo Diesel Common Rail Injection StgV	VDM(Vehicle Dynamic Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																													
MONDEO	2012 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																													
MONDEO	2012 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																													
MONDEO	2012 MY	2.0L DIESEL	SYSTEM SEARCH																																														
MONDEO	2012 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																														
MONDEO	2012 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	2012 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2012 MY	2.0L DIESEL	BCMii(Body Control Module)																																														
MONDEO	2012 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																														
MONDEO	2012 MY	2.0L DIESEL	CMR(Camera Module Rear)																																														
MONDEO	2012 MY	2.0L DIESEL	DDM(Driver's Door Module)																																														
MONDEO	2012 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																														
MONDEO	2012 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																														
MONDEO	2012 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2012 MY	2.0L DIESEL	IPM-A(Image Processing Module A)																																														
MONDEO	2012 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																														
MONDEO	2012 MY	2.0L DIESEL	PAM(Parking Aid Module)																																														
MONDEO	2012 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																														
MONDEO	2012 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																														
MONDEO	2012 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																														
MONDEO	2012 MY	2.0L DIESEL	RCM(Restraint Control Module)																																														
MONDEO	2012 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																														
MONDEO	2012 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																														
MONDEO	2012 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)																																														
MONDEO	2012 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																														
MONDEO	2012 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																														
MONDEO	2012 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																														
MONDEO	2012 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																														
MONDEO	2012 MY	2.0L DIESEL	TCM(Transmission Control Module)																																														
MONDEO	2012 MY	2.0L DIESEL	TRM(Trailer Module)																																														
MONDEO	2012 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																														
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																																														
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																																														
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																																														
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																																														
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																													
MONDEO	2011 MY	1.6L	Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																													
MONDEO	2011 MY	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																													
MONDEO	2011 MY	2.0L DIESEL	SYSTEM SEARCH																																														
MONDEO	2011 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																														
MONDEO	2011 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	2011 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2011 MY	2.0L DIESEL	BCMii(Body Control Module)																																														
MONDEO	2011 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																														
MONDEO	2011 MY	2.0L DIESEL	CMR(Camera Module Rear)																																														
MONDEO	2011 MY	2.0L DIESEL	DDM(Driver's Door Module)																																														
MONDEO	2011 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																														
MONDEO	2011 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																														
MONDEO	2011 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2011 MY	2.0L DIESEL	IPM-A(Image Processing Module A)																																														
MONDEO	2011 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																														
MONDEO	2011 MY	2.0L DIESEL	PAM(Parking Aid Module)																																														
MONDEO	2011 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																														
MONDEO	2011 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																														
MONDEO	2011 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																														
MONDEO	2011 MY	2.0L DIESEL	RCM(Restraint Control Module)																																														
MONDEO	2011 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																														
MONDEO	2011 MY	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																																														
MONDEO	2011 MY	2.0L DIESEL	RHVAC(Rear Heating Ventilation Air Conditioning)																																														
MONDEO	2011 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																														
MONDEO	2011 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																														
MONDEO	2011 MY	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																																														
MONDEO	2011 MY	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																																														
MONDEO	2011 MY	2.0L DIESEL	TCM(Transmission Control Module)																																														
MONDEO	2011 MY	2.0L DIESEL	TRM(Trailer Module)																																														
MONDEO	2011 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	SYSTEM SEARCH																																														
MONDEO	2011 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																																														
MONDEO	2011 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	BCMii(Body Control Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2011 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																														
MONDEO	2011 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2011 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																														
MONDEO	2011 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	TRM(Trailer Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																														
MONDEO	2011 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																														
MONDEO	2011 MY	2.5L GASOLINE	SYSTEM SEARCH																																														
MONDEO	2011 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																														
MONDEO	2011 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	BCMii(Body Control Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																														
MONDEO	2011 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2011 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																														
MONDEO	2011 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	TRM(Trailer Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																														
MONDEO	2011 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2010 MY	2.0L	DIESEL	SYSTEM SEARCH																																													
MONDEO	2010 MY	2.0L	DIESEL	PCM(PowerTrain Control Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	ABS(Anti-Lock Brake System)																																													
MONDEO	2010 MY	2.0L	DIESEL	AHCM(Auxiliary Heater Control Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	BCMii(Body Control Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	CCMii(Cruise Control Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	CMR(Camera Module Rear)																																													
MONDEO	2010 MY	2.0L	DIESEL	DDM(Driver's Door Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	DSM(Driver's Seat Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	HCM(Headlamp Control Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	HVAC(Heating Ventilation Air Conditioning)																																													
MONDEO	2010 MY	2.0L	DIESEL	IPC(Instrument Panel Control Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	PAM(Parking Aid Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	PBM(Parking Brake Control Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	PDM(Passenger's Door Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	PSCM(Power Steering Control Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	RCM(Restraint Control Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	RFA(Remote Function Actuator)																																													
MONDEO	2010 MY	2.0L	DIESEL	SASM(Steering Angle Sensor Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	SRM(Speech Recognition Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	TCM(Transmission Control Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	TRM(Trailer Module)																																													
MONDEO	2010 MY	2.0L	DIESEL	VDM(Vehicle Dynamic Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM(Auxiliary Heater Control Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii(Cruise Control Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP(Compact Disc Player)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR(Camera Module Rear)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DABM(Digital Audio Broadcast Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	NAV(Navigation System)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM(Parking Brake Control Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC(Rear Heating Ventilation Air Conditioning)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM(Speech Recognition Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module - Left)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module - Right)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																																													
MONDEO	2010 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																																													
MONDEO	2010 MY	2.3L GASOLINE	SYSTEM SEARCH																																														
MONDEO	2010 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																																														
MONDEO	2010 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	BCMii(Body Control Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																														
MONDEO	2010 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2010 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																														
MONDEO	2010 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	TRM(Trailer Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																														
MONDEO	2010 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																														
MONDEO	2010 MY	2.5L GASOLINE	SYSTEM SEARCH																																														
MONDEO	2010 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																														
MONDEO	2010 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																														
MONDEO	2010 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2010 MY	2.5L GASOLINE	BCMii(Body Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2010 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																															
MONDEO	2010 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2010 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																															
MONDEO	2010 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	TRM(Trailer Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																															
MONDEO	2010 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																															
MONDEO	2009 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																														
MONDEO	2009 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2009 MY	1.8L DIESEL	SYSTEM SEARCH																																														
MONDEO	2009 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																														
MONDEO	2009 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	2009 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2009 MY	1.8L DIESEL	BCMii(Body Control Module)																																														
MONDEO	2009 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																														
MONDEO	2009 MY	1.8L DIESEL	CMR(Camera Module Rear)																																														
MONDEO	2009 MY	1.8L DIESEL	DDM(Driver's Door Module)																																														
MONDEO	2009 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																														
MONDEO	2009 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																														
MONDEO	2009 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2009 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																														
MONDEO	2009 MY	1.8L DIESEL	PAM(Parking Aid Module)																																														
MONDEO	2009 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																																														
MONDEO	2009 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																														
MONDEO	2009 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																														
MONDEO	2009 MY	1.8L DIESEL	RCM(Restraint Control Module)																																														
MONDEO	2009 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																														
MONDEO	2009 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																														
MONDEO	2009 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																														
MONDEO	2009 MY	1.8L DIESEL	TRM(Trailer Module)																																														
MONDEO	2009 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																														
MONDEO	2009 MY	2.0L DIESEL	SYSTEM SEARCH																																														
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																														
MONDEO	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																														
MONDEO	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																																														
MONDEO	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	2009 MY	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																																														
MONDEO	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																																														
MONDEO	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																																														
MONDEO	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																																														
MONDEO	2009 MY	2.0L DIESEL	CCMii(Cruise Control Module)																																														
MONDEO	2009 MY	2.0L DIESEL	CMR(Camera Module Rear)																																														
MONDEO	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																																														
MONDEO	2009 MY	2.0L DIESEL	DSM(Driver's Seat Module)																																														
MONDEO	2009 MY	2.0L DIESEL	HCM(Headlamp Control Module)																																														
MONDEO	2009 MY	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2009 MY	2.0L DIESEL	PAM(Parking Aid Module)																																														
MONDEO	2009 MY	2.0L DIESEL	PBM(Parking Brake Control Module)																																														
MONDEO	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																																														
MONDEO	2009 MY	2.0L DIESEL	PSCM(Power Steering Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2009 MY	2.0L DIESEL	RFA(Remote Function Actuator)																																														
MONDEO	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																														
MONDEO	2009 MY	2.0L DIESEL	TRM(Trailer Module)																																														
MONDEO	2009 MY	2.0L DIESEL	VDM(Vehicle Dynamic Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	SYSTEM SEARCH																																														
MONDEO	2009 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																																														
MONDEO	2009 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	BCMii(Body Control Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																														
MONDEO	2009 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2009 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																														
MONDEO	2009 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	TRM(Trailer Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																														
MONDEO	2009 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																														
MONDEO	2009 MY	2.5L GASOLINE	SYSTEM SEARCH																																														
MONDEO	2009 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																														
MONDEO	2009 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																														
MONDEO	2009 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2009 MY	2.5L GASOLINE	BCMii(Body Control Module)																																														
MONDEO	2009 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																														
MONDEO	2009 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																														
MONDEO	2009 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																														
MONDEO	2009 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																														
MONDEO	2009 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																														
MONDEO	2009 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2009 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																														
MONDEO	2009 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																														
MONDEO	2009 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2009 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																															
MONDEO	2009 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																															
MONDEO	2009 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																															
MONDEO	2009 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																															
MONDEO	2009 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																															
MONDEO	2009 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																															
MONDEO	2009 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																															
MONDEO	2009 MY	2.5L GASOLINE	TRM(Trailer Module)																																															
MONDEO	2009 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																															
MONDEO	2009 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																															
MONDEO	2008 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																														
MONDEO	2008 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																														
MONDEO	2008 MY	1.8L DIESEL	SYSTEM SEARCH																																															
MONDEO	2008 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																															
MONDEO	2008 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																															
MONDEO	2008 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																															
MONDEO	2008 MY	1.8L DIESEL	BCMii(Body Control Module)																																															
MONDEO	2008 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																															
MONDEO	2008 MY	1.8L DIESEL	CMR(Camera Module Rear)																																															
MONDEO	2008 MY	1.8L DIESEL	DDM(Driver's Door Module)																																															
MONDEO	2008 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2008 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																														
MONDEO	2008 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2008 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																														
MONDEO	2008 MY	1.8L DIESEL	PAM(Parking Aid Module)																																														
MONDEO	2008 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																																														
MONDEO	2008 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																														
MONDEO	2008 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																														
MONDEO	2008 MY	1.8L DIESEL	RCM(Restraint Control Module)																																														
MONDEO	2008 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																														
MONDEO	2008 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																														
MONDEO	2008 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																														
MONDEO	2008 MY	1.8L DIESEL	TRM(Trailer Module)																																														
MONDEO	2008 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	SYSTEM SEARCH																																														
MONDEO	2008 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																																														
MONDEO	2008 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	BCMii(Body Control Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																														
MONDEO	2008 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2008 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																														
MONDEO	2008 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	TRM(Trailer Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																														
MONDEO	2008 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																														
MONDEO	2008 MY	2.5L GASOLINE	SYSTEM SEARCH																																														
MONDEO	2008 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																														
MONDEO	2008 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																														
MONDEO	2008 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2008 MY	2.5L GASOLINE	BCMii(Body Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2008 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																															
MONDEO	2008 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																															
MONDEO	2008 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																															
MONDEO	2008 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	TRM(Trailer Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																															
MONDEO	2008 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																															
MONDEO	2007 MY	1.6L	DURATEC VCT	SYSTEM SEARCH																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	ACM(Audio Control Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	BCMii(Body Control Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	CCMii(Cruise Control Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	CMR(Camera Module Rear)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	DDM(Driver's Door Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	DSM(Driver's Seat Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	PAM(Parking Aid Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	PBM(Parking Brake Control Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	RCM(Restraint Control Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	TRM(Trailer Module)																																														
MONDEO	2007 MY	1.6L	DURATEC VCT	VDM(Vehicle Dynamic Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2007 MY	1.8L DIESEL	SYSTEM SEARCH																																														
MONDEO	2007 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																														
MONDEO	2007 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	2007 MY	1.8L DIESEL	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2007 MY	1.8L DIESEL	BCMii(Body Control Module)																																														
MONDEO	2007 MY	1.8L DIESEL	CCMii(Cruise Control Module)																																														
MONDEO	2007 MY	1.8L DIESEL	CMR(Camera Module Rear)																																														
MONDEO	2007 MY	1.8L DIESEL	DDM(Driver's Door Module)																																														
MONDEO	2007 MY	1.8L DIESEL	DSM(Driver's Seat Module)																																														
MONDEO	2007 MY	1.8L DIESEL	HCM(Headlamp Control Module)																																														
MONDEO	2007 MY	1.8L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2007 MY	1.8L DIESEL	IPC(Instrument Panel Control Module)																																														
MONDEO	2007 MY	1.8L DIESEL	PAM(Parking Aid Module)																																														
MONDEO	2007 MY	1.8L DIESEL	PBM(Parking Brake Control Module)																																														
MONDEO	2007 MY	1.8L DIESEL	PDM(Passenger's Door Module)																																														
MONDEO	2007 MY	1.8L DIESEL	PSCM(Power Steering Control Module)																																														
MONDEO	2007 MY	1.8L DIESEL	RCM(Restraint Control Module)																																														
MONDEO	2007 MY	1.8L DIESEL	RFA(Remote Function Actuator)																																														
MONDEO	2007 MY	1.8L DIESEL	SASM(Steering Angle Sensor Module)																																														
MONDEO	2007 MY	1.8L DIESEL	SRM(Speech Recognition Module)																																														
MONDEO	2007 MY	1.8L DIESEL	TRM(Trailer Module)																																														
MONDEO	2007 MY	1.8L DIESEL	VDM(Vehicle Dynamic Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	SYSTEM SEARCH																																														
MONDEO	2007 MY	2.3L GASOLINE	PCM(PowerTrain Control Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	ABS(Anti-Lock Brake System)																																														
MONDEO	2007 MY	2.3L GASOLINE	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	BCMii(Body Control Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	CCMii(Cruise Control Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	CMR(Camera Module Rear)																																														
MONDEO	2007 MY	2.3L GASOLINE	DDM(Driver's Door Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	DSM(Driver Seat Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	HCM(HeadLamp Control Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2007 MY	2.3L GASOLINE	IPC(Instrument Panel Control Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	PAM(Parking Aid Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	PBM(Parking Brake Control Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	PDM(Passenger's Door Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	PSCM(Power Steering Control Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	RCM(Restraint Control Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	RFA(Remote Function Actuator)																																														
MONDEO	2007 MY	2.3L GASOLINE	SASM(Steering Angle Sensor Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	SRM(Speech Recognition Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2007 MY	2.3L GASOLINE	TCM(Transmission Control Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	TRM(Trailer Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	VDM(Vehicle Dynamics Module)																																														
MONDEO	2007 MY	2.3L GASOLINE	PATS(Passive Anti Theft System)-BETA																																														
MONDEO	2007 MY	2.5L GASOLINE	SYSTEM SEARCH																																														
MONDEO	2007 MY	2.5L GASOLINE	PCM(PowerTrain Control Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	ABS(Anti-Lock Brake System)																																														
MONDEO	2007 MY	2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	BCMii(Body Control Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	CCMii(Cruise Control Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	CMR(Camera Module Rear)																																														
MONDEO	2007 MY	2.5L GASOLINE	DDM(Driver's Door Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	DSM(Driver's Seat Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	HCM(Headlamp Control Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																														
MONDEO	2007 MY	2.5L GASOLINE	IPC(Instrument Panel Control Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	PAM(Parking Aid Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	PBM(Parking Brake Control Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	PDM(Passenger's Door Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	PSCM(Power Steering Control Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	RCM(Restraint Control Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	RFA(Remote Function Actuator)																																														
MONDEO	2007 MY	2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	SRM(Speech Recognition Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	TCM(Transmission Control Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	TRM(Trailer Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																														
MONDEO	2007 MY	2.5L GASOLINE	PATS(Passive Anti Theft System)-BETA																																														
MONDEO	2003 MY	2.0L DIESEL	SYSTEM SEARCH																																														
MONDEO	2003 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																														
MONDEO	2003 MY	2.0L DIESEL	TCM(Transmission Control Module)																																														
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	2003 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	2003 MY	2.0L DIESEL	CSM(Central Security Module)																																														
MONDEO	2003 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																														
MONDEO	2003 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																														
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																														
MONDEO	2003 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																														
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																														
MONDEO	2003 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																														
MONDEO	2003 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																														
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2003 MY	2.0L DIESEL	RCM(Restraint Control Module)																																															
MONDEO	2003 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																															
MONDEO	2003 MY	2.0L DIESEL	ACM(Audio Control Module)																																															
MONDEO	2003 MY	2.0L DIESEL	CDP(Compact Disc Player)																																															
MONDEO	2003 MY	2.0L DIESEL	GDM(Generic Display Module)																																															
MONDEO	2003 MY	2.0L DIESEL	NAV(Navigation System)																																															
MONDEO	2003 MY	2.0L DIESEL	RETM(Rear Entertainment Module)																																															
MONDEO	2003 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																															
MONDEO	2003 MY	2.0L DIESEL	ICU(Injector Control Unit)																																															
MONDEO	2003 MY	2.0L DIESEL	PATS(Passive Anti Theft System)																																															
MONDEO	2002 MY	2.0L DIESEL	SYSTEM SEARCH																																															
MONDEO	2002 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																															
MONDEO	2002 MY	2.0L DIESEL	TCM(Transmission Control Module)																																															
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																															
MONDEO	2002 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																															
MONDEO	2002 MY	2.0L DIESEL	CSM(Central Security Module)																																															
MONDEO	2002 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																															
MONDEO	2002 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																															
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																															
MONDEO	2002 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																															
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																															
MONDEO	2002 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																															
MONDEO	2002 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																															
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)																																															
MONDEO	2002 MY	2.0L DIESEL	RCM(Restraint Control Module)																																															
MONDEO	2002 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																															
MONDEO	2002 MY	2.0L DIESEL	ACM(Audio Control Module)																																															
MONDEO	2002 MY	2.0L DIESEL	CDP(Compact Disc Player)																																															
MONDEO	2002 MY	2.0L DIESEL	GDM(Generic Display Module)																																															
MONDEO	2002 MY	2.0L DIESEL	NAV(Navigation System)																																															
MONDEO	2002 MY	2.0L DIESEL	RETM(Rear Entertainment Module)																																															
MONDEO	2002 MY	2.0L DIESEL	SRM(Speech Recognition Module)																																															
MONDEO	2002 MY	2.0L DIESEL	ICU(Injector Control Unit)																																															
MONDEO	2002 MY	2.0L DIESEL	PATS(Passive Anti Theft System)																																															
MONDEO	2002 MY	2.0L GASOLINE	SYSTEM SEARCH																																															
MONDEO	2002 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)																																															
MONDEO	2002 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																															
MONDEO	2002 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																															
MONDEO	2002 MY	2.0L GASOLINE	GEM(Generic Electronic Module)																																															
MONDEO	2002 MY	2.0L GASOLINE	HCM(Headlamp Control Module)																																															
MONDEO	2002 MY	2.0L GASOLINE	RCM(Restraint Control Module)																																															
MONDEO	2001 MY	2.0L DIESEL	SYSTEM SEARCH																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	2001 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																																														
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	2001 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	2001 MY	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																																														
MONDEO	2001 MY	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																														
MONDEO	2001 MY	2.0L DIESEL	GEM(Generic Electronic Module)																																														
MONDEO	2001 MY	2.0L DIESEL	HEC(Hybrid Electrical Cluster)																																														
MONDEO	2001 MY	2.0L DIESEL	LHID(Left High Intensity Discharge Lamp)																																														
MONDEO	2001 MY	2.0L DIESEL	RCM(Restraint Control Module)																																														
MONDEO	2001 MY	2.0L DIESEL	RHID(Right High Intensity Discharge Lamp)																																														
MONDEO	2001 MY	2.0L DIESEL	ACM(Audio Control Module)																																														
MONDEO	2001 MY	2.0L GASOLINE	SYSTEM SEARCH																																														
MONDEO	2001 MY	2.0L GASOLINE	PCM(PowerTrain Control Module)																																														
MONDEO	2001 MY	2.0L GASOLINE	ABS(Anti-Lock Brake System)																																														
MONDEO	2001 MY	2.0L GASOLINE	EATC(Electronic Automatic Temperature Control)																																														
MONDEO	2001 MY	2.0L GASOLINE	GEM(Generic Electronic Module)																																														
MONDEO	2001 MY	2.0L GASOLINE	HCM(Headlamp Control Module)																																														
MONDEO	2001 MY	2.0L GASOLINE	RCM(Restraint Control Module)																																														
MONDEO	2000 MY	1.8L	SYSTEM SEARCH																																														
MONDEO	2000 MY	1.8L	PCM(PowerTrain Control Module)																																														
MONDEO	2000 MY	1.8L	ABS(Anti-Lock Brake System)																																														
MONDEO	2000 MY	1.8L	CSM(Central Security Module)																																														
MONDEO	2000 MY	1.8L DIESEL	SYSTEM SEARCH																																														
MONDEO	2000 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																														
MONDEO	2000 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	2000 MY	1.8L DIESEL	CSM(Central Security Module)																																														
MONDEO	2000 MY	1.8L DIESEL	Passive Antitheft																																														
MONDEO	2000 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																														
MONDEO	2000 MY	2.0L	SYSTEM SEARCH																																														
MONDEO	2000 MY	2.0L	PCM(PowerTrain Control Module)																																														
MONDEO	2000 MY	2.0L	ABS(Anti-Lock Brake System)																																														
MONDEO	2000 MY	2.0L	CSM(Central Security Module)																																														
MONDEO	2000 MY	2.5L	SYSTEM SEARCH																																														
MONDEO	2000 MY	2.5L	PCM(PowerTrain Control Module)																																														
MONDEO	2000 MY	2.5L	ABS(Anti-Lock Brake System)																																														
MONDEO	2000 MY	2.5L	CSM(Central Security Module)																																														
MONDEO	1999 MY	1.8L	SYSTEM SEARCH																																														
MONDEO	1999 MY	1.8L	PCM(PowerTrain Control Module)																																														
MONDEO	1999 MY	1.8L	ABS(Anti-Lock Brake System)																																														
MONDEO	1999 MY	1.8L	CSM(Central Security Module)																																														
MONDEO	1999 MY	1.8L DIESEL	SYSTEM SEARCH																																														
MONDEO	1999 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MONDEO	1999 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	1999 MY	1.8L DIESEL	CSM(Central Security Module)																																														
MONDEO	1999 MY	1.8L DIESEL	Passive Antitheft																																														
MONDEO	1999 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																														
MONDEO	1999 MY	2.0L	SYSTEM SEARCH																																														
MONDEO	1999 MY	2.0L	PCM(PowerTrain Control Module)																																														
MONDEO	1999 MY	2.0L	ABS(Anti-Lock Brake System)																																														
MONDEO	1999 MY	2.0L	CSM(Central Security Module)																																														
MONDEO	1999 MY	2.5L	SYSTEM SEARCH																																														
MONDEO	1999 MY	2.5L	PCM(PowerTrain Control Module)																																														
MONDEO	1999 MY	2.5L	ABS(Anti-Lock Brake System)																																														
MONDEO	1999 MY	2.5L	CSM(Central Security Module)																																														
MONDEO	1998 MY	1.8L	SYSTEM SEARCH																																														
MONDEO	1998 MY	1.8L	PCM(PowerTrain Control Module)																																														
MONDEO	1998 MY	1.8L	ABS(Anti-Lock Brake System)																																														
MONDEO	1998 MY	1.8L	CSM(Central Security Module)																																														
MONDEO	1998 MY	1.8L DIESEL	SYSTEM SEARCH																																														
MONDEO	1998 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																														
MONDEO	1998 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	1998 MY	1.8L DIESEL	CSM(Central Security Module)																																														
MONDEO	1998 MY	1.8L DIESEL	Passive Antitheft																																														
MONDEO	1998 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																														
MONDEO	1998 MY	2.0L	SYSTEM SEARCH																																														
MONDEO	1998 MY	2.0L	PCM(PowerTrain Control Module)																																														
MONDEO	1998 MY	2.0L	ABS(Anti-Lock Brake System)																																														
MONDEO	1998 MY	2.0L	CSM(Central Security Module)																																														
MONDEO	1998 MY	2.5L	SYSTEM SEARCH																																														
MONDEO	1998 MY	2.5L	PCM(PowerTrain Control Module)																																														
MONDEO	1998 MY	2.5L	ABS(Anti-Lock Brake System)																																														
MONDEO	1998 MY	2.5L	CSM(Central Security Module)																																														
MONDEO	1997 MY	1.8L	PCM(PowerTrain Control Module)																																														
MONDEO	1997 MY	1.8L	ABS(Anti-Lock Brake System)																																														
MONDEO	1997 MY	1.8L DIESEL	SYSTEM SEARCH																																														
MONDEO	1997 MY	1.8L DIESEL	PCM(PowerTrain Control Module)																																														
MONDEO	1997 MY	1.8L DIESEL	ABS(Anti-Lock Brake System)																																														
MONDEO	1997 MY	1.8L DIESEL	Passive Antitheft																																														
MONDEO	1997 MY	1.8L DIESEL	RIM(Remote Immobilizer Module)																																														
MONDEO	1997 MY	2.0L	PCM(PowerTrain Control Module)																																														
MONDEO	1997 MY	2.0L	ABS(Anti-Lock Brake System)																																														
MONDEO	1997 MY	2.5L	PCM(PowerTrain Control Module)																																														
MONDEO	1997 MY	2.5L	ABS(Anti-Lock Brake System)																																														
MOUNTAINEER	2010 MY	4.6L	SYSTEM SEARCH																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MOUNTAINEER	2010 MY	4.6L	PCM(Powertrain Control Module)																																															
MOUNTAINEER	2010 MY	4.6L	TCM(Transmission Control Module)																																															
MOUNTAINEER	2010 MY	4.6L	4X4(4x4 Control Module)																																															
MOUNTAINEER	2010 MY	4.6L	ABS(Anti-Lock Brake System)																																															
MOUNTAINEER	2010 MY	4.6L	ACM(Audio Control Module)																																															
MOUNTAINEER	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																																															
MOUNTAINEER	2010 MY	4.6L	GPSM(Global Positioning System Module)																																															
MOUNTAINEER	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																															
MOUNTAINEER	2010 MY	4.6L	DSM(Driver's Seat Module)																																															
MOUNTAINEER	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																															
MOUNTAINEER	2010 MY	4.6L	IC(Instrument Cluster)																																															
MOUNTAINEER	2010 MY	4.6L	OCSM(Occupant Classification System Module)																																															
MOUNTAINEER	2010 MY	4.6L	PAM(Parking Aid Module)																																															
MOUNTAINEER	2010 MY	4.6L	PRB(Power Running Board)																																															
MOUNTAINEER	2010 MY	4.6L	RCM(Restraint Control Module)																																															
MOUNTAINEER	2010 MY	4.6L	RETM(Rear Entertainment Module)																																															
MOUNTAINEER	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																															
MOUNTAINEER	2009 MY	4.6L	SYSTEM SEARCH																																															
MOUNTAINEER	2009 MY	4.6L	PCM(Powertrain Control Module)																																															
MOUNTAINEER	2009 MY	4.6L	TCM(Transmission Control Module)																																															
MOUNTAINEER	2009 MY	4.6L	4X4(4x4 Control Module)																																															
MOUNTAINEER	2009 MY	4.6L	ABS(Anti-Lock Brake System)																																															
MOUNTAINEER	2009 MY	4.6L	ACM(Audio Control Module)																																															
MOUNTAINEER	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																																															
MOUNTAINEER	2009 MY	4.6L	GPSM(Global Positioning System Module)																																															
MOUNTAINEER	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																																															
MOUNTAINEER	2009 MY	4.6L	DSM(Driver's Seat Module)																																															
MOUNTAINEER	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																															
MOUNTAINEER	2009 MY	4.6L	IC(Instrument Cluster)																																															
MOUNTAINEER	2009 MY	4.6L	OCSM(Occupant Classification System Module)																																															
MOUNTAINEER	2009 MY	4.6L	PAM(Parking Aid Module)																																															
MOUNTAINEER	2009 MY	4.6L	PRB(Power Running Board)																																															
MOUNTAINEER	2009 MY	4.6L	RCM(Restraint Control Module)																																															
MOUNTAINEER	2009 MY	4.6L	RETM(Rear Entertainment Module)																																															
MOUNTAINEER	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																																															
MUSTANG	4.0L V6 SOHC			SYSTEM SEARCH																																														
MUSTANG	4.0L V6 SOHC			PCM(Powertrain Control Module)																																														
MUSTANG	4.0L V6 SOHC			ABS(Anti-Lock Brake System)																																														
MUSTANG	4.0L V6 SOHC			ACM(Audio Control Module)																																														
MUSTANG	4.0L V6 SOHC			APIM(Accessory Protocol Interface Module)																																														
MUSTANG	4.0L V6 SOHC			GEM/SJB(Generic Electronic Module/Smart Junction Box)																																														
MUSTANG	4.0L V6 SOHC			RCM(Restraint Control Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
MUSTANG	4.0L V6 SOHC			SDARS(Satellite Digital Audio Receiver System)																																													
MUSTANG	4.0L V6 SOHC			IC(Instrument Cluster)																																													
TAURUS	2011 MY	3.5L	SYSTEM SEARCH																																														
TAURUS	2011 MY	3.5L	PCM(PowerTrain Control Module)																																														
TAURUS	2011 MY	3.5L	4X4(4x4 Control Module)																																														
TAURUS	2011 MY	3.5L	ABS(Anti-Lock Brake System)																																														
TAURUS	2011 MY	3.5L	ACM(Audio Control Module)																																														
TAURUS	2011 MY	3.5L	APIM(Accessory Protocol Interface Module)																																														
TAURUS	2011 MY	3.5L	C-CM(Cruise Control Module)																																														
TAURUS	2011 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																														
TAURUS	2011 MY	3.5L	DDM(Driver's Door Module)																																														
TAURUS	2011 MY	3.5L	DSM(Driver's Seat Module)																																														
TAURUS	2011 MY	3.5L	DSP(Digital Signal Processing Module)																																														
TAURUS	2011 MY	3.5L	FCIM(Front Controls Interface Module)																																														
TAURUS	2011 MY	3.5L	FDIM(Front Display Interface Module)																																														
TAURUS	2011 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																														
TAURUS	2011 MY	3.5L	GPSM(Global Positioning System Module)																																														
TAURUS	2011 MY	3.5L	HCM(Headlamp Control Module)																																														
TAURUS	2011 MY	3.5L	HCM-2(Headlamp Control Module2)																																														
TAURUS	2011 MY	3.5L	HUD(Head Up Display)																																														
TAURUS	2011 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																														
TAURUS	2011 MY	3.5L	ILCM(Interior Lighting Control Module)																																														
TAURUS	2011 MY	3.5L	IPC(Instrument Panel Control Module)																																														
TAURUS	2011 MY	3.5L	OCSM(Occupant Classification System Module)																																														
TAURUS	2011 MY	3.5L	PAM(Parking Aid Module)																																														
TAURUS	2011 MY	3.5L	PSCM(Power Steering Control Module)																																														
TAURUS	2011 MY	3.5L	RCM(Restraint Control Module)																																														
TAURUS	2011 MY	3.5L	RETM(Rear Entertainment Module)																																														
TAURUS	2011 MY	3.5L	RFA(Remote Function Actuator)																																														
TAURUS	2011 MY	3.5L	SASM(Steering Angle Sensor Module)																																														
TAURUS	2011 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																														
TAURUS	2011 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																														
TAURUS	2010 MY	3.5L	SYSTEM SEARCH																																														
TAURUS	2010 MY	3.5L	PCM(PowerTrain Control Module)																																														
TAURUS	2010 MY	3.5L	4X4(4x4 Control Module)																																														
TAURUS	2010 MY	3.5L	ABS(Anti-Lock Brake System)																																														
TAURUS	2010 MY	3.5L	ACM(Audio Control Module)																																														
TAURUS	2010 MY	3.5L	APIM(Accessory Protocol Interface Module)																																														
TAURUS	2010 MY	3.5L	C-CM(Cruise Control Module)																																														
TAURUS	2010 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																														
TAURUS	2010 MY	3.5L	DDM(Driver's Door Module)																																														
TAURUS	2010 MY	3.5L	DSM(Driver's Seat Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
TAURUS	2010 MY	3.5L	DSP(Digital Signal Processing Module)																																														
TAURUS	2010 MY	3.5L	FCIM(Front Controls Interface Module)																																														
TAURUS	2010 MY	3.5L	FDIM(Front Display Interface Module)																																														
TAURUS	2010 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																														
TAURUS	2010 MY	3.5L	GPSM(Global Positioning System Module)																																														
TAURUS	2010 MY	3.5L	HCM(Headlamp Control Module)																																														
TAURUS	2010 MY	3.5L	HCM-2(Headlamp Control Module2)																																														
TAURUS	2010 MY	3.5L	HUD(Head Up Display)																																														
TAURUS	2010 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																														
TAURUS	2010 MY	3.5L	ILCM(Interior Lighting Control Module)																																														
TAURUS	2010 MY	3.5L	IPC(Instrument Panel Control Module)																																														
TAURUS	2010 MY	3.5L	OCSM(Occupant Classification System Module)																																														
TAURUS	2010 MY	3.5L	PAM(Parking Aid Module)																																														
TAURUS	2010 MY	3.5L	PSCM(Power Steering Control Module)																																														
TAURUS	2010 MY	3.5L	RCM(Restraint Control Module)																																														
TAURUS	2010 MY	3.5L	RETM(Rear Entertainment Module)																																														
TAURUS	2010 MY	3.5L	RFA(Remote Function Actuator)																																														
TAURUS	2010 MY	3.5L	SASM(Steering Angle Sensor Module)																																														
TAURUS	2010 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																														
TAURUS	2010 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																														
TAURUS	2009 MY	3.5L	SYSTEM SEARCH																																														
TAURUS	2009 MY	3.5L	PCM(PowerTrain Control Module)																																														
TAURUS	2009 MY	3.5L	4X4(4x4 Control Module)																																														
TAURUS	2009 MY	3.5L	ABS(Anti-Lock Brake System)																																														
TAURUS	2009 MY	3.5L	ACM(Audio Control Module)																																														
TAURUS	2009 MY	3.5L	APIM(Accessory Protocol Interface Module)																																														
TAURUS	2009 MY	3.5L	C-CM(Cruise Control Module)																																														
TAURUS	2009 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																														
TAURUS	2009 MY	3.5L	DDM(Driver's Door Module)																																														
TAURUS	2009 MY	3.5L	DSM(Driver's Seat Module)																																														
TAURUS	2009 MY	3.5L	DSP(Digital Signal Processing Module)																																														
TAURUS	2009 MY	3.5L	FCIM(Front Controls Interface Module)																																														
TAURUS	2009 MY	3.5L	FDIM(Front Display Interface Module)																																														
TAURUS	2009 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																														
TAURUS	2009 MY	3.5L	GPSM(Global Positioning System Module)																																														
TAURUS	2009 MY	3.5L	HCM(Headlamp Control Module)																																														
TAURUS	2009 MY	3.5L	HCM-2(Headlamp Control Module2)																																														
TAURUS	2009 MY	3.5L	HUD(Head Up Display)																																														
TAURUS	2009 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																														
TAURUS	2009 MY	3.5L	ILCM(Interior Lighting Control Module)																																														
TAURUS	2009 MY	3.5L	IPC(Instrument Panel Control Module)																																														
TAURUS	2009 MY	3.5L	OCSM(Occupant Classification System Module)																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
TAURUS	2009 MY	3.5L	PAM(Parking Aid Module)																																															
TAURUS	2009 MY	3.5L	PSCM(Power Steering Control Module)																																															
TAURUS	2009 MY	3.5L	RCM(Restraint Control Module)																																															
TAURUS	2009 MY	3.5L	RETM(Rear Entertainment Module)																																															
TAURUS	2009 MY	3.5L	RFA(Remote Function Actuator)																																															
TAURUS	2009 MY	3.5L	SASM(Steering Angle Sensor Module)																																															
TAURUS	2009 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																															
TAURUS	2009 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																															
TAURUS	2008 MY	3.5L	SYSTEM SEARCH																																															
TAURUS	2008 MY	3.5L	PCM(PowerTrain Control Module)																																															
TAURUS	2008 MY	3.5L	4X4(4x4 Control Module)																																															
TAURUS	2008 MY	3.5L	ABS(Anti-Lock Brake System)																																															
TAURUS	2008 MY	3.5L	ACM(Audio Control Module)																																															
TAURUS	2008 MY	3.5L	APIM(Accessory Protocol Interface Module)																																															
TAURUS	2008 MY	3.5L	C-CM(Cruise Control Module)																																															
TAURUS	2008 MY	3.5L	DCSM(Driver-Dual Climate Contol Seat Module)																																															
TAURUS	2008 MY	3.5L	DDM(Driver's Door Module)																																															
TAURUS	2008 MY	3.5L	DSM(Driver's Seat Module)																																															
TAURUS	2008 MY	3.5L	DSP(Digital Signal Processing Module)																																															
TAURUS	2008 MY	3.5L	FCIM(Front Controls Interface Module)																																															
TAURUS	2008 MY	3.5L	FDIM(Front Display Interface Module)																																															
TAURUS	2008 MY	3.5L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																															
TAURUS	2008 MY	3.5L	GPSM(Global Positioning System Module)																																															
TAURUS	2008 MY	3.5L	HCM(Headlamp Control Module)																																															
TAURUS	2008 MY	3.5L	HCM-2(Headlamp Control Module2)																																															
TAURUS	2008 MY	3.5L	HUD(Head Up Display)																																															
TAURUS	2008 MY	3.5L	HVAC(Heating Ventilation Air Conditioning)																																															
TAURUS	2008 MY	3.5L	ILCM(Interior Lighting Control Module)																																															
TAURUS	2008 MY	3.5L	IPC(Instrument Panel Control Module)																																															
TAURUS	2008 MY	3.5L	OCSM(Occupant Classification System Module)																																															
TAURUS	2008 MY	3.5L	PAM(Parking Aid Module)																																															
TAURUS	2008 MY	3.5L	PSCM(Power Steering Control Module)																																															
TAURUS	2008 MY	3.5L	RCM(Restraint Control Module)																																															
TAURUS	2008 MY	3.5L	RETM(Rear Entertainment Module)																																															
TAURUS	2008 MY	3.5L	RFA(Remote Function Actuator)																																															
TAURUS	2008 MY	3.5L	SASM(Steering Angle Sensor Module)																																															
TAURUS	2008 MY	3.5L	SOD-L(Side Obstacle Detection Control Module Left)																																															
TAURUS	2008 MY	3.5L	SOD-R(Side Obstacle Detection Control Module Right)																																															
TAURUS	1998 MY	SYSTEM SEARCH																																																
TAURUS	1998 MY	PCM(PowerTrain Control Module)																																																
TAURUS	1998 MY	ABS(Anti-Lock Brake System)																																																
TAURUS	1998 MY	RCM(Restraint Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
TAURUS	1998 MY	RIM(Remote Immobilizer Module)																																															
TAURUS	1997 MY	SYSTEM SEARCH																																															
TAURUS	1997 MY	PCM(PowerTrain Control Module)																																															
TAURUS	1997 MY	ABS(Anti-Lock Brake System)																																															
TAURUS	1997 MY	RCM(Restraint Control Module)																																															
TAURUS	1997 MY	RIM(Remote Immobilizer Module)																																															
TAURUS	1996 MY	SYSTEM SEARCH																																															
TAURUS	1996 MY	PCM(PowerTrain Control Module)																																															
TAURUS	1996 MY	ABS(Anti-Lock Brake System)																																															
TAURUS	1996 MY	RCM(Restraint Control Module)																																															
TAURUS	1996 MY	RIM(Remote Immobilizer Module)																																															
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	SYSTEM SEARCH																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PCM(PowerTrain Control Module)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	TCM(Transmission Control Module)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ABS(Anti-Lock Brake System)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	ACM(Audio Control Module)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	APIM(Accessory Protocol Interface Module)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	BEM(Body Electronic Module)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	FCIM(Front Controls Interface Module)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GPSM(Global Positioning System Module)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	GWM(Gateway Module A)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	HIM(HVAC Integrated Module)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	IPC(Instrument Panel Control Module)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PAM(Parking Aid Module)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	PSCM(Power Steering Control Module)																																													
TERRITORY	2014~	4.0L GASOLINE	SZ2-Beta	RCM(Restraint Control Module)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	SYSTEM SEARCH																																													
TERRITORY	2010~	4.0L GASOLINE	SY	PCM(Powertrain Control Module)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	TCM(Transmission Control Module)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	ABS(Anti-Lock Brake System)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	ACM(Audio Control Module)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	PSCM(Power Steering Control Module)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	BEM(Body Electronic Module)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	HIM(HVAC Integrated Module)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	IC(Instrument Cluster)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	PAM(Parking Aid Module)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)																																													
TERRITORY	2010~	4.0L GASOLINE	SY	RCM(Restraint Control Module)																																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
TERRITORY	2010~	4.0L GASOLINE	SY	FDIM(Front Display Interface Module)																																													
TERRITORY	2010~	2.7L DIESEL	SZ	SYSTEM SEARCH																																													
TERRITORY	2010~	2.7L DIESEL	SZ	PCM(Powertrain Control Module)																																													
TERRITORY	2010~	2.7L DIESEL	SZ	ABS(Anti-Lock Brake System)																																													
TERRITORY	2010~	2.7L DIESEL	SZ	ACM(Audio Control Module)																																													
TERRITORY	2010~	2.7L DIESEL	SZ	AWD(All Wheel Drive Module)																																													
TERRITORY	2010~	2.7L DIESEL	SZ	BEM(Body Electronic Module)																																													
TERRITORY	2010~	2.7L DIESEL	SZ	FDIM(Front Display Interface Module)																																													
TERRITORY	2010~	2.7L DIESEL	SZ	HIM(HVAC Intergrated Module)																																													
TERRITORY	2010~	2.7L DIESEL	SZ	IPC(Instrument Panel Control Module)																																													
TERRITORY	2010~	2.7L DIESEL	SZ	PAM(Parking Aid Module)																																													
TERRITORY	2010~	2.7L DIESEL	SZ	PSCM(Power Steering Control Module)																																													
TERRITORY	2010~	2.7L DIESEL	SZ	RCM(Restraint Control Module)																																													
TERRITORY	2010~	2.7L DIESEL	SZ	TCM(Transmission Control Module)																																													
TERRITORY	2009~2010	SYSTEM SEARCH																																															
TERRITORY	2009~2010	PCM(PowerTrain Control Module)																																															
TERRITORY	2009~2010	TCM(Transmission Control Module)																																															
TERRITORY	2009~2010	ABS(Anti-Lock Brake System)																																															
TERRITORY	2009~2010	RCM(Restraint Control Module)																																															
TERRITORY	2009~2010	BEM(Body Electronic Module)																																															
TERRITORY	2009~2010	IC(Instrument Cluster)																																															
TERRITORY	2009~2010	HIM(HVAC Integrated Module)																																															
TERRITORY	2009~2010	ACM(Audio Control Module)																																															
TERRITORY	2005~2009	SYSTEM SEARCH																																															
TERRITORY	2005~2009	PCM(PowerTrain Control Module)																																															
TERRITORY	2005~2009	TCM(Transmission Control Module)																																															
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)																																															
TERRITORY	2005~2009	ABS(Anti-Lock Brake System)																																															
TERRITORY	2005~2009	RCM(Restraint Control Module)																																															
TERRITORY	2005~2009	BEM(Body Electronic Module)																																															
TERRITORY	2005~2009	IC(Instrument Cluster)																																															
TERRITORY	2005~2009	HIM(HVAC Integrated Module)																																															
TERRITORY	2005~2009	ACM(Audio Control Module)																																															
TERRITORY	2004~2005	SYSTEM SEARCH																																															
TERRITORY	2004~2005	PCM(PowerTrain Control Module)																																															
TERRITORY	2004~2005	ABS(Anti-Lock Brake System)																																															
TERRITORY	2004~2005	RCM(Restraint Control Module)																																															
TERRITORY	2004~2005	BEM(Body Electronic Module)																																															
TERRITORY	2004~2005	IC(Instrument Cluster)																																															
TERRITORY	2004~2005	HIM(HVAC Integrated Module)																																															
TERRITORY	2004~2005	HIM(HVAC Integrated Module)																																															
TERRITORY	2004~2005	ACM(Audio Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
TERRITORY	2004~2005	PAM(Parking Aid Module)																																															
TRANSIT	1.6L DIESEL	SYSTEM SEARCH																																															
TRANSIT	1.6L DIESEL	PCM(PowerTrain Control Module)																																															
TRANSIT	1.6L DIESEL	ABS(Anti-Lock Brake System)																																															
TRANSIT	1.6L DIESEL	ACM(Audio Control Module)																																															
TRANSIT	1.6L DIESEL	AHCM(Auxiliary Heater Control Module)																																															
TRANSIT	1.6L DIESEL	APIM(Accessory Protocol Interface Module)																																															
TRANSIT	1.6L DIESEL	BCMii(Body Control Module)																																															
TRANSIT	1.6L DIESEL	DDM(Driver's Door Module)																																															
TRANSIT	1.6L DIESEL	FCIM(Front Controls Interface Module)																																															
TRANSIT	1.6L DIESEL	FDSM(Front Distance Sensing Module)																																															
TRANSIT	1.6L DIESEL	FCDIM(Front Control/Display Interface Module)																																															
TRANSIT	1.6L DIESEL	GPSM(Global Positioning System Module)																																															
TRANSIT	1.6L DIESEL	HCM(Headlamp Control Module)																																															
TRANSIT	1.6L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																															
TRANSIT	1.6L DIESEL	IPM-B(Image Processing Module B)																																															
TRANSIT	1.6L DIESEL	IPC(Instrument Panel Control Module)																																															
TRANSIT	1.6L DIESEL	PAM(Parking Aid Module)																																															
TRANSIT	1.6L DIESEL	PDM(Passenger's Door Module)																																															
TRANSIT	1.6L DIESEL	PSCM(Power Steering Control Module)			V																																												
TRANSIT	1.6L DIESEL	RCM(Restraint Control Module)																																															
TRANSIT	1.6L DIESEL	SASM(Steering Angle Sensor Module)																																															
TRANSIT	1.6L DIESEL	TRM(Trailer Module)																																															
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)																																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)																																													
TRANSIT	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)																																													
TRANSIT	2.0L	SYSTEM SEARCH																																															
TRANSIT	2.0L	PCM(PowerTrain Control Module)				V																																											
TRANSIT	2.0L	PATS(Passive Anti Theft System)																																															
TRANSIT	2.0L	ASM(Auto Shift Manual)					V	V	V	V	V																																						
TRANSIT	2.0L	ABS(Anti-Lock Brake System)																																															
TRANSIT	2.0L	HEC(Hybrid Electrical Cluster)																																															
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SYSTEM SEARCH																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PCM(PowerTrain Control Module)								V	V																																					
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)										V																																			
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ABS(Anti-Lock Brake System)										V	V																																			
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	ACM(Audio Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	APIM(Accessory Protocol Interface Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	AHCM(Auxiliary Heater Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	BCMii(Body Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	CCMii(Cruise Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FCDIM(Front Control/Display Interface Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	GPSM(Global Positioning System Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	HCM(Headlamp Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-A(Image Processing Module A)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPM-B(Image Processing Module B)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	FFH(Fuel Fired Coolant Heating Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	IPC(Instrument Panel Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PAM(Parking Aid Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	PRB(Power Running Board)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	RCM(Restraint Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SRM(Speech Recognition Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	SASM(Steering Angle Sensor Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TBC(Trailer Brake Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection StgV	2014 ~	TRM(Trailer Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SYSTEM SEARCH																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PCM(PowerTrain Control Module)								V	V																																					
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)										V																																			
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ABS(Anti-Lock Brake System)										V	V																																			
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	ACM(Audio Control Module)																																													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	APIM(Accessory Protocol Interface Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	AHCM(Auxiliary Heater Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	BCMii(Body Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	CCMii(Cruise Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FCDIM(Front Control/Display Interface Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	GPSM(Global Positioning System Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	HCM(Headlamp Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-A(Image Processing Module A)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPM-B(Image Processing Module B)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	FFH(Fuel Fired Coolant Heating Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	IPC(Instrument Panel Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PAM(Parking Aid Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	PRB(Power Running Board)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	RCM(Restraint Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SRM(Speech Recognition Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	SASM(Steering Angle Sensor Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TBC(Trailer Brake Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	2010~	TRM(Trailer Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	SYSTEM SEARCH																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)		V																																											
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PCM(PowerTrain Control Module)												V	V	V	V	V																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	PATS(Passive Anti Theft System)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ASM(Auto Shift Manual)			V	V	V	V	V																																						
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ABS(Anti-Lock Brake System)										V	V																																		
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	RCM(Restraint Control Module)																	V																												
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	HEC(Hybrid Electrical Cluster)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	IPC(Instrument Panel Control Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	BCMii(Body Control Module)																		V	V																											
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	CSM(Central Security Module)																																													
TRANSIT	2.2L DIESEL	Duratorq-Turbo Diesel Common Rail Injection	~2009	ACM(Audio Control Module)																																													
TRANSIT	2.3L DIESEL	SYSTEM SEARCH																																															
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)				V																																											
TRANSIT	2.3L DIESEL	PCM(PowerTrain Control Module)														V	V	V	V	V																													
TRANSIT	2.3L DIESEL	PATS(Passive Anti Theft System)																																															
TRANSIT	2.3L DIESEL	ASM(Auto Shift Manual)					V	V	V	V	V																																						
TRANSIT	2.3L DIESEL	ABS(Anti-Lock Brake System)												V	V																																		

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
TRANSIT	2.3L DIESEL	RCM(Restraint Control Module)																			V																													
TRANSIT	2.3L DIESEL	HEC(Hybrid Electrical Cluster)																																																
TRANSIT	2.3L DIESEL	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.3L DIESEL	BCMii(Body Control Module)																				V	V																											
TRANSIT	2.3L DIESEL	ACM(Audio Control Module)																																																
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SYSTEM SEARCH																																															
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PCM(PowerTrain Control Module)																																															
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ABS(Anti-Lock Brake System)																					V	V	V																								
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	ACM(Audio Control Module)																																															
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	BCMii(Body Control Module)																								V	V																						
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																															
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	IPC(Instrument Panel Control Module)																																															
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	PAM(Parking Aid Module)																																															
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	RCM(Restraint Control Module)																																															
TRANSIT	2.3L GASOLINE	DURATEC-HE-I4	SRM(Speech Recognition Module)																																															
TRANSIT	2.4L DIESEL	SYSTEM SEARCH																																																
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)				V																																												
TRANSIT	2.4L DIESEL	PCM(PowerTrain Control Module)														V	V	V	V	V																														
TRANSIT	2.4L DIESEL	PATS(Passive Anti Theft System)																																																
TRANSIT	2.4L DIESEL	ASM(Auto Shift Manual)					V	V	V	V	V																																							
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)																																																
TRANSIT	2.4L DIESEL	ABS(Anti-Lock Brake System)												V	V																																			
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)																																																
TRANSIT	2.4L DIESEL	RCM(Restraint Control Module)																			V																													
TRANSIT	2.4L DIESEL	HEC(Hybrid Electrical Cluster)																																																
TRANSIT	2.4L DIESEL	IPC(Instrument Panel Control Module)																																																
TRANSIT	2.4L DIESEL	BCMii(Body Control Module)																				V	V																											
TRANSIT	2.4L DIESEL	CSM(Central Security Module)																																																
TRANSIT	2.4L DIESEL	ACM(Audio Control Module)																																																
TRANSIT	2.5L DIESEL	SYSTEM SEARCH																																																
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)				V																																												
TRANSIT	2.5L DIESEL	PCM(PowerTrain Control Module)																																																
TRANSIT	2.5L DIESEL	PATS(Passive Anti Theft System)																																																
TRANSIT	2.5L DIESEL	ASM(Auto Shift Manual)					V	V	V	V	V																																							
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																																															
TRANSIT	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																																															
TRANSIT	2.5L DIESEL	RCM(Restraint Control Module)																																																
TRANSIT	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																																																
TRANSIT	2.5L DIESEL	CSM(Central Security Module)																																																
TRANSIT	2.5L DIESEL	Passive Antitheft																																																
TRANSIT	2.5L DIESEL	RIM(Remote Immobilizer Module)																																																
TRANSIT	2.5L DIESEL	ACM(Audio Control Module)																																																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
TRANSIT	3.2L DIESEL	SYSTEM SEARCH																																															
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)				V																																											
TRANSIT	3.2L DIESEL	PCM(PowerTrain Control Module)														V	V	V	V	V																													
TRANSIT	3.2L DIESEL	ABS(Anti-Lock Brake System)												V	V																																		
TRANSIT	3.2L DIESEL	ACM(Audio Control Module)																																															
TRANSIT	3.2L DIESEL	BCMii(Body Control Module)																																															
TRANSIT	3.2L DIESEL	FFH(Fuel Fired Coolant Heating Module)																																															
TRANSIT	3.2L DIESEL	IPC(Instrument Panel Control Module)																																															
TRANSIT	3.2L DIESEL	PAM(Parking Aid Module)																																															
TRANSIT	3.2L DIESEL	RCM(Restraint Control Module)																																															
TRANSIT	3.2L DIESEL	SRM(Speech Recognition Module)																																															
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	SYSTEM SEARCH																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PCM(PowerTrain Control Module)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ABS(Anti-Lock Brake System)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	CSM(Central Security Module)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ECS(Electronic Crash Sensor)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	FFH(Fuel Fired Coolant Heating Module)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	HEC(Hybrid Electrical Cluster)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	ICU(Injector Control Unit)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PAM(Parking Aid Module)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	RCM(Restraint Control Module)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2002.5MY	PATS(Passive Anti Theft System)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SYSTEM SEARCH																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PCM(PowerTrain Control Module)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ABS(Anti-Lock Brake System)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	ACM(Audio Control Module)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	GEM(Generic Electronic Module)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	IC(Instrument Cluster)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	PAM(Parking Aid Module)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	RCM(Restraint Control Module)																																													
TOURNEO	1.8L	Duratorq-Turbo Diesel Common Rail Injection	2007 MY ~	SRM(Speech Recognition Module)																																													
RANGER	2.2 Diesel	SYSTEM SEARCH																																															
RANGER	2.2 Diesel	PCM(PowerTrain Control Module)																																															
RANGER	2.2 Diesel	ABS(Anti-Lock Brake System)																											V																				
RANGER	2.2 Diesel	ACM(Audio Control Module)																																															
RANGER	2.2 Diesel	BCMii(Body Control Module)																																															
RANGER	2.2 Diesel	DDM(Driver's Door Module)																																															
RANGER	2.2 Diesel	FCDIM(Front Control/Display Interface Module)																																															
RANGER	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
RANGER	2.2 Diesel	IPC(Instrument Panel Control Module)																																															
RANGER	2.2 Diesel	PAM(Parking Aid Module)																																															
RANGER	2.2 Diesel	PDM(Passenger's Door Module)																																															
RANGER	2.2 Diesel	RCM(Restraint Control Module)																																															
RANGER	2.2 Diesel	SRM(Speech Recognition Module)																																															
RANGER	2.2 Diesel	TBM(Tracking And Blocking Module)																												V	V																		
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																															
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																															
RANGER	2.2 Diesel	TCM(Transmission Control Module)																																															
RANGER	2.2 Diesel	TRM(Trailer Module)																																															
RANGER	2.2 Diesel	PATS(Passive anti theft system)-BETA																																															
RANGER	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																															
RANGER	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																														V	V	V															
RANGER	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																																															
RANGER	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																																															
RANGER	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																																															
RANGER	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)-BETA																																															
RANGER	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																															
RANGER	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																														V	V	V															
RANGER	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																																															
RANGER	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																																															
RANGER	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																																															
RANGER	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)-BETA																																															
RANGER	3.2 Diesel	~ 2015	SYSTEM SEARCH																																														
RANGER	3.2 Diesel	~ 2015	PCM(PowerTrain Control Module)																																V														
RANGER	3.2 Diesel	~ 2015	ABS(Anti-Lock Brake System)																									V																					
RANGER	3.2 Diesel	~ 2015	ACM(Audio Control Module)																																														
RANGER	3.2 Diesel	~ 2015	BCMii(Body Control Module)																																	V													
RANGER	3.2 Diesel	~ 2015	DDM(Driver's Door Module)																																														
RANGER	3.2 Diesel	~ 2015	FCDIM(Front Control/Display Interface Module)																																														
RANGER	3.2 Diesel	~ 2015	HVAC(Heating Ventilation Air Conditioning)																																														
RANGER	3.2 Diesel	~ 2015	IPC(Instrument Panel Control Module)																																														
RANGER	3.2 Diesel	~ 2015	PAM(Parking Aid Module)																																														
RANGER	3.2 Diesel	~ 2015	PDM(Passenger's Door Module)																																														
RANGER	3.2 Diesel	~ 2015	RCM(Restraint Control Module)																																														
RANGER	3.2 Diesel	~ 2015	SRM(Speech Recognition Module)																																														
RANGER	3.2 Diesel	~ 2015	TBM(Tracking And Blocking Module)																											V	V																		
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																														
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																														
RANGER	3.2 Diesel	~ 2015	TCM(Transmission Control Module)																																														
RANGER	3.2 Diesel	~ 2015	TRM(Trailer Module)																																														
RANGER	3.2 Diesel	~ 2015	PATS(Passive anti theft system)-BETA																																														

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
RANGER	3.2 Diesel	2015 ~	SYSTEM SEARCH																																														
RANGER	3.2 Diesel	2015 ~	PCM(PowerTrain Control Module)																																	V	V												
RANGER	3.2 Diesel	2015 ~	TCM(Transmission Control Module)																																														
RANGER	3.2 Diesel	2015 ~	ABS(Anti-Lock Brake System)																																														
RANGER	3.2 Diesel	2015 ~	ACM(Audio Control Module)																																														
RANGER	3.2 Diesel	2015 ~	APIM(Accessory Protocol Interface Module)																																														
RANGER	3.2 Diesel	2015 ~	ATCM(All Terrain Control Module)																																														
RANGER	3.2 Diesel	2015 ~	BCM(Body Control Module)																																														
RANGER	3.2 Diesel	2015 ~	C-CM(Cruise Control Module)																																														
RANGER	3.2 Diesel	2015 ~	DDM(Driver's Door Module)																																														
RANGER	3.2 Diesel	2015 ~	FCDIM(Front Control/Display Interface Module)																																														
RANGER	3.2 Diesel	2015 ~	FCIM(Front Controls Interface Module)																																			V											
RANGER	3.2 Diesel	2015 ~	GPSM(Global Positioning System Module)																																														
RANGER	3.2 Diesel	2015 ~	GWM(Gateway Module A)																																														
RANGER	3.2 Diesel	2015 ~	HCM(Headlamp Control Module)																																														
RANGER	3.2 Diesel	2015 ~	HUD(Head Up Display)																																														
RANGER	3.2 Diesel	2015 ~	IPC(Instrument Panel Control Module)																																														
RANGER	3.2 Diesel	2015 ~	IPM-A(Image Processing Module A)																																														
RANGER	3.2 Diesel	2015 ~	PAM(Parking Aid Module)																																														
RANGER	3.2 Diesel	2015 ~	PDM(Passenger's Door Module)																																														
RANGER	3.2 Diesel	2015 ~	PSCM(Power Steering Control Module)																																														
RANGER	3.2 Diesel	2015 ~	RCM(Restraint Control Module)																																														
RANGER	3.2 Diesel	2015 ~	RGTM(Rear Gate/Trunk Module)																																														
RANGER	3.2 Diesel	2015 ~	RTM(Radio Transceiver Module)																																														
RANGER	3.2 Diesel	2015 ~	SCCM(Streering Colume Control Module)																																														
RANGER	3.2 Diesel	2015 ~	TCU(Telemetic Control Unit Module)																																														
RANGER	3.2 Diesel	2015 ~	TRM(Trailer Module)																																														
RANGER	2.5 Gasoline	SYSTEM SEARCH																																															
RANGER	2.5 Gasoline	PCM(PowerTrain Control Module)																																															
RANGER	2.5 Gasoline	ABS(Anti-Lock Brake System)																											V																				
RANGER	2.5 Gasoline	ACM(Audio Control Module)																																															
RANGER	2.5 Gasoline	BCMii(Body Control Module)																																															
RANGER	2.5 Gasoline	DDM(Driver's Door Module)																																															
RANGER	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																																															
RANGER	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																																															
RANGER	2.5 Gasoline	IPC(Instrument Panel Control Module)																																															
RANGER	2.5 Gasoline	PAM(Parking Aid Module)																																															
RANGER	2.5 Gasoline	PDM(Passenger's Door Module)																																															
RANGER	2.5 Gasoline	RCM(Restraint Control Module)																																															
RANGER	2.5 Gasoline	SRM(Speech Recognition Module)																																															
RANGER	2.5 Gasoline	TBM(Tracking And Blocking Module)																												V	V																		
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																															
RANGER	2.5 Gasoline	TCM(Transmission Control Module)																																															
RANGER	2.5 Gasoline	TRM(Trailer Module)																																															
RANGER	2.5 Gasoline	PATS(Passive anti theft system)-BETA																																															
BETA-TEST	FOCUS-1.6L Zetec Rocam	SYSTEM SEARCH																																															
BETA-TEST	FOCUS-1.6L Zetec Rocam	PCM(PowerTrain Control Module)																																															
BETA-TEST	FOCUS-1.6L Zetec Rocam	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FOCUS-1.6L Zetec Rocam	EATC(Electronic Automatic Temperature Control)																																															
BETA-TEST	FOCUS-1.6L Zetec Rocam	GEM(Generic Electronic Module)																																															
BETA-TEST	FOCUS-1.6L Zetec Rocam	HCM(Headlamp Control Module)																																															
BETA-TEST	FOCUS-1.6L Zetec Rocam	MC(Message Center)																																															
BETA-TEST	FOCUS-1.6L Zetec Rocam	RCM(Restraint Control Module)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SYSTEM SEARCH																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	ACM(Audio Control Module)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CDP(Compact Disc Player)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	CMR(Camera Module Rear)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	D_DCU(Driver Door Control Unit)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	EPS(Electronic Power Steering)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	FFH(Fuel Fired Coolant Heating Module)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	HCM(Headlamp Control Module)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	IC(Instrument Cluster)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PAM(Parking Aid Module)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	PDM(Passenger's Door Module)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RCM(Restraint Control Module)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RETM(Rear Entertainment Module)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RKE(Remote Keyless Entry)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	GDM(Generic Display Module)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	NAV(Navigation System)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RL_DCU(Rear Left Door Control Unit)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	RR_DCU(Rear Right Door Control Unit)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)																																															
BETA-TEST	FOCUS-1.6L DURATEC Gasoline	TCM(Transmission Control Module)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	SYSTEM SEARCH																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PCM(PowerTrain Control Module)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	ACM(Audio Control Module)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CDP(Compact Disc Player)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	CMR(Camera Module Rear)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	D_DCU(Driver Door Control Unit)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EATC(Electronic Automatic Temperature Control)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	EPS(Electronic Power Steering)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FACM(Fuel Additive Control Module)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	GEM(Generic Electronic Module)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	HCM(Headlamp Control Module)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	IC(Instrument Cluster)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PAM(Parking Aid Module)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	PDM(Passenger's Door Module)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RCM(Restraint Control Module)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RETM(Rear Entertainment Module)																																															
BETA-TEST	FOCUS-1.6L DURATORQ-Turbo Diesel	RKE(Remote Keyless Entry)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SYSTEM SEARCH																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PCM(PowerTrain Control Module)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	ACM(Audio Control Module)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	CDP(Compact Disc Player)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	EPS(Electronic Power Steering)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GDM(Generic Display Module)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	GEM(Generic Electronic Module)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	IC(Instrument Cluster)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	NAV(Navigation System)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PAM(Parking Aid Module)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	PDM(Passenger's Door Module)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RETM(Rear Entertainment Module)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RKE(Remote Keyless Entry)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	SRM(Speech Recognition Module)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	HCM(Headlamp Control Module)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	RCM(Restraint Control Module)																																															
BETA-TEST	FOCUS-1.8L DURATEC-HE-I4	TCM(Transmission Control Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SYSTEM SEARCH																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PCM(PowerTrain Control Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	ACM(Audio Control Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	CDP(Compact Disc Player)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	D_DCU(Driver Door Control Unit)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EATC(Electronic Automatic Temperature Control)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	EPS(Electronic Power Steering)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GDM(Generic Display Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	FFH(Fuel Fired Coolant Heating Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	GEM(Generic Electronic Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	IC(Instrument Cluster)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	NAV(Navigation System)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PAM(Parking Aid Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	PDM(Passenger's Door Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RETM(Rear Entertainment Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RKE(Remote Keyless Entry)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RL_DCU(Rear Left Door Control Unit)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RR_DCU(Rear Right Door Control Unit)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	SRM(Speech Recognition Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	HCM(Headlamp Control Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4	RCM(Restraint Control Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	SYSTEM SEARCH																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PCM(Powertrain Control Module)																																				V											
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	ACM(Audio Control Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	D_DCU(Driver Door Control Unit)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EATC(Electronic Automatic Temperature Control)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	EPS(Electronic power steering)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	GEM(Generic Electronic Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	HCM(Headlamp Control Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	IC(Instrument Cluster)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PAM(Parking Aid Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PDM(Passenger's Door Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RCM(Restraint Control Module)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	RKE(Remote Keyless Entry)																																															
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TBM(Tracking and Blocking Module)																												V	V																		
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	TCM(Transmission Control Module)																																					V										
BETA-TEST	FOCUS-2.0L DURATEC-HE-I4 2008 ~ 2011	PATS(Passive Anti Theft System)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	SYSTEM SEARCH																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PCM(PowerTrain Control Module)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CDP(Compact Disc Player)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	CMR(Camera Module Rear)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	D_DCU(Driver Door Control Unit)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EATC(Electronic Automatic Temperature Control)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	EPS(Electronic Power Steering)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FACM(Fuel Additive Control Module)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	FFH(Fuel Fired Coolant Heating Module)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	GEM(Generic Electronic Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	HCM(Headlamp Control Module)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	IC(Instrument Cluster)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PDM(Passenger's Door Module)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	PAM(Parking Aid Module)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RCM(Restraint Control Module)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RETM(Rear Entertainment Module)																																															
BETA-TEST	FOCUS-2.0L Duratorq Turbo Diesel	RKE(Remote Keyless Entry)																																															
BETA-TEST	FUSION GASOLINE1.4L	SYSTEM SEARCH																																															
BETA-TEST	FUSION GASOLINE1.4L	PCM(Powertrain Control Module)																																															
BETA-TEST	FUSION GASOLINE1.4L	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FUSION GASOLINE1.4L	ACM(Audio Control Module)																																															
BETA-TEST	FUSION GASOLINE1.4L	APIM(Accessory Protocol Interface Module)																																															
BETA-TEST	FUSION GASOLINE1.4L	BCMii(Body Control Module)																																															
BETA-TEST	FUSION GASOLINE1.4L	DDM(Driver's Door Module)																																															
BETA-TEST	FUSION GASOLINE1.4L	FDSM(Front Distance Sensing Module)																																															
BETA-TEST	FUSION GASOLINE1.4L	FCDIM(Front Control/Display Interface Module)																																															
BETA-TEST	FUSION GASOLINE1.4L	GPSM(Global Positioning System Module)																																															
BETA-TEST	FUSION GASOLINE1.4L	GWM(Gateway Module A)																																															
BETA-TEST	FUSION GASOLINE1.4L	HVAC(Heating Ventilation Air Conditioning)																																															
BETA-TEST	FUSION GASOLINE1.4L	IPC(Instrument Panel Control Module)																																															
BETA-TEST	FUSION GASOLINE1.4L	PDM(Passenger's Door Module)																																															
BETA-TEST	FUSION GASOLINE1.4L	PSCM(Power Steering Control Module)																																															
BETA-TEST	FUSION GASOLINE1.4L	RCM(Restraint Control Module)																																															
BETA-TEST	FUSION GASOLINE1.4L	RFA(Remote Function Actuator)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SYSTEM SEARCH																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PCM(PowerTrain Control Module)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	TCM(Transmission Control Module)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IC(Instrument Cluster)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	GEM(Generic Electronic Module)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	ACM(Audio Control Module)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	BCMii(Body Control Module)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	FCDIM(Front Control/Display Interface Module)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	IPC(Instrument Panel Control Module)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	PSCM(Power Steering Control Module)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RCM(Retraint Control Module)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	RFA(Remote Function Actuator)																																															
BETA-TEST	FIESTA-1.4L Duratorq-Turbo Diesel	SRM(Speech Recognition Module)																																															
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SYSTEM SEARCH																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	PCM(PowerTrain Control Module)																																															
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	TCM(Transmission Control Module)																																															
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	IC(Instrument Cluster)																																															
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	ACM(Audio Control Module)																																															
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	EATC(Electronic Automatic Temperature Control)																																															
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	GEM(Generic Electronic Module)																																															
BETA-TEST	FIESTA-1.6L DURATEC Gasoline	SRM(Speech Recognition Module)																																															
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	SYSTEM SEARCH																																															
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																																															
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																																															
BETA-TEST	FIESTA-1.8L ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																																															
BETA-TEST	FIESTA 1.6L DURATEC 16V	SYSTEM SEARCH																																															
BETA-TEST	FIESTA 1.6L DURATEC 16V	PCM(PowerTrain Control Module)																																															
BETA-TEST	FIESTA 1.6L DURATEC 16V	TCM(Transmission Control Module)																																															
BETA-TEST	FIESTA 1.6L DURATEC 16V	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FIESTA 1.6L DURATEC 16V	IC(Instrument Cluster)																																															
BETA-TEST	FIESTA 1.6L DURATEC 16V	ACM(Audio Control Module)																																															
BETA-TEST	FIESTA 1.6L DURATEC 16V	EATC(Electronic Automatic Temperature Control)																																															
BETA-TEST	FIESTA 1.6L DURATEC 16V	GEM(Generic Electronic Module)																																															
BETA-TEST	FIESTA 1.6L DURATEC 16V	SRM(Speech Recognition Module)																																															
BETA-TEST	FIESTA 1.6L DURATEC 16V	PATS(Passive Anti Theft System)																																															
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SYSTEM SEARCH																																															
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PCM(PowerTrain Control Module)																																															
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ABS(Anti-Lock Brake System)																																															
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	ACM(Audio Control Module)																																															
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	EATC(Electronic Automatic Temperature Control)																																															
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	GEM(Generic Electronic Module)																																															
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	IC(Instrument Cluster)																																															
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	SRM(Speech Recognition Module)																																															
BETA-TEST	FIESTA 2.0L 3-door DURATEC-HEI4	PATS(Passive Anti Theft System)																																															
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	SYSTEM SEARCH																																															
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PCM(PowerTrain Control Module)																																															
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	ABS(Anti-Lock Brake System)																																															
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	IC(Instrument Cluster)																																															
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RCM(Restraint Control Module)																																															
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	RKE(Remote Keyless Entry)																																															
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	TCM(Transmission Control Module)																																															
BETA-TEST	S.A Fiesta Zetec Rocam 1.6 Gasoline	PATS(Passive Anti Theft System)																																															
BETA-TEST	MONDEO-2.0L DIESEL	SYSTEM SEARCH																																															
BETA-TEST	MONDEO-2.0L DIESEL	PCM(PowerTrain Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
BETA-TEST	MONDEO-2.0L DIESEL	ABS(Anti-Lock Brake System)																																															
BETA-TEST	MONDEO-2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	BCMii(Body Control Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	CCMii(Cruise Control Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	CMR(Camera Module Rear)																																															
BETA-TEST	MONDEO-2.0L DIESEL	DDM(Driver's Door Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	DSM(Driver's Seat Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	HCM(Headlamp Control Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																																															
BETA-TEST	MONDEO-2.0L DIESEL	IPC(Instrument Panel Control Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	PAM(Parking Aid Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	PBM(Parking Brake Control Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	PDM(Passenger's Door Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	PSCM(Power Steering Control Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	RCM(Restraint Control Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	RFA(Remote Function Actuator)																																															
BETA-TEST	MONDEO-2.0L DIESEL	SASM(Steering Angle Sensor Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	SRM(Speech Recognition Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	TCM(Transmission Control Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	TRM(Trailer Module)																																															
BETA-TEST	MONDEO-2.0L DIESEL	VDM(Vehicle Dynamic Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	SYSTEM SEARCH																																															
BETA-TEST	MONDEO-2.5L GASOLINE	PCM(PowerTrain Control Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	ABS(Anti-Lock Brake System)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	AHCM(Auxiliary Heater Control Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	BCMii(Body Control Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	CCMii(Cruise Control Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	CMR(Camera Module Rear)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	DDM(Driver's Door Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	DSM(Driver's Seat Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	HCM(Headlamp Control Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	HVAC(Heating Ventilation Air Conditioning)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	IPC(Instrument Panel Control Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	PAM(Parking Aid Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	PBM(Parking Brake Control Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	PDM(Passenger's Door Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	PSCM(Power Steering Control Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	RCM(Restraint Control Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	RFA(Remote Function Actuator)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	SASM(Steering Angle Sensor Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	SRM(Speech Recognition Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	TCM(Transmission Control Module)																																															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Pull Drift Compensation Reset	Injector programming	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Reset the Power Train Control Module Learned Values	Reset the Vehicle Speed Limit	Calibration longitudinal acceleration sensor	Reset pressure sensor offset	Fuel injector pilot correction learn	Fuel injection pump learn	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	RCM configuration(Beta)	Igniton key erase	Ignition key program	Reset pressure sensor Offset	Calibrate Longitudinal Acceleration Sensor	Enable/Disable hill Launch Assist	CAR Mode	Parking Light Configuration	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	TBM SIM RAV ID	Reset TBM Password	MAF Correction	PCM reset	MAF sensor reset	Ambient Air Temp Sensor Configuration	Battery monitoring system reset(Beta)	Reset the Intake Air Throttle Valve Learned	Reset DPF Differential Pressure Sensor Learned Values	FCIM Module Installation	Reset Charge Air Cooler Bypass Valve Position Offset	Reset Transmission Tables	Program additional Ignition Key	Ignition Key Code Erase and Program	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Unlimited Key Mode OFF	Unlimited Key Mode ON	Program Unlimited Key Code	Vehicle Data Log Capture
BETA-TEST	MONDEO-2.5L GASOLINE	TRM(Trailer Module)																																															
BETA-TEST	MONDEO-2.5L GASOLINE	VDM(Vehicle Dynamic Module)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	SYSTEM SEARCH																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	PCM(PowerTrain Control Module)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	ABS(Anti-Lock Brake System)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	ACM(Audio Control Module)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	CDP(Compact Disc Player)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	GDM(Generic Display Module)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	GEM(Generic Electronic Module)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	NAV(Navigation System)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	RCM(Restraint Control Module)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	RETM(Rear Entertainment Module)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																																															
BETA-TEST	MONDEO-3.0L Duratec-ST	SRM(Speech Recognition Module)																																															
BETA-TEST	F-150 5.4L	SYSTEM SEARCH																																															
BETA-TEST	F-150 5.4L	PCM(PowerTrain Control Module)																																															
BETA-TEST	F-150 5.4L	4X4(4x4 Control Module)																																															
BETA-TEST	F-150 5.4L	ABS(Anti-Lock Brake System)																																															
BETA-TEST	F-150 5.4L	DSM(Driver Seat Module)																																															
BETA-TEST	F-150 5.4L	EATC(Electronic Automatic Temperature Control)																																															
BETA-TEST	F-150 5.4L	IC(Instrument Cluster)																																															
BETA-TEST	F-150 5.4L	PAM(Parking Aid Module)																																															
BETA-TEST	F-150 5.4L	RCM(Restraint Control Module)																																															
BETA-TEST	F-150 5.4L	VSM(Vehicle Security Module)																																															
BETA-TEST	F-150 5.4L	PATS(Passive Anti Theft System)																																								V	V	V	V	V	V	V	
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	SYSTEM SEARCH																																															
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PCM(PowerTrain Control Module)																																															
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	ABS(Anti-Lock Brake System)																																															
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	IC(Instrument Cluster)																																															
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	PAM(Parking Aid Module)																																															
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	RCM(Restraint Control Module)																																															
BETA-TEST	E-series EXTENDED SPORT VAN 5.4L V8 FI SOHC	VSM(Vehicle Security Module)																																															
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																															V
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																															V
BETA-TEST	Vehicle Log Capture	Vehicle Log Capture																																															V

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Vehicle Info.	Vehicle Info.	Vehicle Info.				V																								
Ford	Crown Victoria	4.6L	2V	SYSTEM SEARCH																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)			V	V	V	V																				
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Crown Victoria	4.6L	2V	DDM(Driver's Door Module)			V	V	V	V														V	V	V	V	V	V	
Ford	Crown Victoria	4.6L	2V	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Crown Victoria	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)			V	V	V																					
Ford	Crown Victoria	4.6L	2V	LCM(Lighting Control Module)			V	V	V	V																				
Ford	Crown Victoria	4.6L	2V	MC(Message Center)			V	V	V																					
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)			V	V	V																					
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)			V	V	V														V							
Ford	Crown Victoria	4.6L	2V	RIM(Remote Immobilizer Module)			V	V	V	V													V							
Ford	Crown Victoria	4.6L	2V	GEM(Generic Electronic Module)			V	V	V	V													V							
Ford	Crown Victoria	4.6L	2V	VDM(Vehicle Dynamic Module)			V	V	V	V			V																	V
Ford	Ecosport	1.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)			V	V	V		V	V	V	V	V															
Ford	Ecosport	1.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Ecosport	1.0L	ZETEC ROCAM	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Ecosport	1.0L	ZETEC ROCAM	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Ecosport	1.0L	ZETEC ROCAM	RCM(Restraint Control Module)			V	V	V																					
Ford	Ecosport	1.4L	DIESEL	SYSTEM SEARCH																										
Ford	Ecosport	1.4L	DIESEL	PCM(PowerTrain Control Module)			V	V	V		V	V	V	V																
Ford	Ecosport	1.4L	DIESEL	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Ecosport	1.4L	DIESEL	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Ecosport	1.4L	DIESEL	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Ecosport	1.4L	DIESEL	RCM(Restraint Control Module)			V	V	V																					
Ford	Ecosport	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)			V	V	V		V	V	V	V	V															
Ford	Ecosport	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Ecosport	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Ecosport	1.6L	ZETEC ROCAM	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Ecosport	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)			V	V	V																					
Ford	Ecosport	1.6L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	FFV	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3		Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Ecosport	1.6L	FFV	ABS(Anti-Lock Brake System)				V	V	V	V																				
Ford	Ecosport	1.6L	FFV	GEM(Generic Electronic Module)				V	V	V	V																				
Ford	Ecosport	1.6L	FFV	IC(Instrument Cluster)				V	V	V	V			V																	
Ford	Ecosport	1.6L	FFV	RCM(Restraint Control Module)				V	V	V																					
Ford	Ecosport	1.6L	FFV	TBM(Tracking And Blocking Module)				V	V	V																					
Ford	Ecosport	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																											
Ford	Ecosport	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)				V	V	V		V	V	V	V	V															
Ford	Ecosport	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)				V	V	V	V																				
Ford	Ecosport	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)				V	V	V	V																				
Ford	Ecosport	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)				V	V	V	V			V																	
Ford	Ecosport	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)				V	V	V																					
Ford	Ecosport	2.0L	ZETEC ROCAM	SYSTEM SEARCH																											
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)				V	V	V		V	V	V	V	V															
Ford	Ecosport	2.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)				V	V	V	V																				
Ford	Ecosport	2.0L	ZETEC ROCAM	IC(Instrument Cluster)				V	V	V	V			V																	
Ford	Ecosport	2.0L	ZETEC ROCAM	RCM(Restraint Control Module)				V	V	V																					
Ford	Ecosport	2.0L	FFV	SYSTEM SEARCH																											
Ford	Ecosport	2.0L	FFV	PCM(PowerTrain Control Module)				V	V	V	V	V	V	V	V	V															
Ford	Ecosport	2.0L	FFV	ABS(Anti-Lock Brake System)				V	V	V	V																				
Ford	Ecosport	2.0L	FFV	GEM(Generic Electronic Module)				V	V	V	V																				
Ford	Ecosport	2.0L	FFV	IC(Instrument Cluster)				V	V	V	V			V																	
Ford	Ecosport	2.0L	FFV	RCM(Restraint Control Module)				V	V	V																					
Ford	Ecosport	2.0L	FFV	TBM(Tracking And Blocking Module)				V	V	V																					
Ford	Escort	2.0L	SYSTEM SEARCH																												
Ford	Escort	2.0L	PCM(PowerTrain Control Module)					V	V	V	V					V	V	V	V	V											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)					V	V	V	V											V									
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)					V	V	V	V											V									
Ford	Escort	2.0L	ECS(Electronic Crash Sensor)					V		V																					
Ford	Escort	2.0L	PATS(Passive Anti Theft System)					V	V	V	V																				
Ford	Escort	2.0L	RAP(Remote Anti-Theft/Personality Module)					V	V	V																					
Ford	Edge	3.5L	4V	SYSTEM SEARCH																											
Ford	Edge	3.5L	4V	PCM(PowerTrain Control Module)				V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Edge	3.5L	4V	4X4(4x4 Control Module)				V	V	V	V			V																	
Ford	Edge	3.5L	4V	ABS(Anti-Lock Brake System)				V	V	V	V			V								V	V								
Ford	Edge	3.5L	4V	ACM(Audio Control Module)				V	V	V		V		V																	
Ford	Edge	3.5L	4V	ACM(Audio Control Module)				V	V	V	V			V																	
Ford	Edge	3.5L	4V	APIM(Accessory Protocol Interface Module)				V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Edge	3.5L	4V	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	Edge	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Ford	Edge	3.5L	4V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Edge	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Ford	Edge	3.5L	4V	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Edge	3.5L	4V	LTM(Liftgate/Trunk Module)			V	V	V				V																	
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	Edge	3.5L	4V	PAM(Parking Aid Module)			V	V	V	V			V																	
Ford	Edge	3.5L	4V	RCM(Restraint Control Module)			V	V	V				V																	
Ford	Edge	3.5L	4V	RETM(Rear Entertainment Module)			V	V	V				V																	
Ford	Edge	3.5L	4V	SASM(Steering Angle Sensor Module)			V	V	V				V																	
Ford	Edge	3.5L	4V	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Ford	Edge	3.5L	4V	TBM(Tracking And Blocking Module)			V	V	V																					
Ford	Edge	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.5L	TiVCT	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Edge	3.5L	TiVCT	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Edge	3.5L	TiVCT	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Edge	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Edge	3.5L	TiVCT	BCM(Body Control Module)			V	V	V	V	V		V											V						
Ford	Edge	3.5L	TiVCT	C-CM(Cruise Control Module)			V	V	V		V		V																	
Ford	Edge	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V																				
Ford	Edge	3.5L	TiVCT	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)			V	V	V	V	V		V																	
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Edge	3.5L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	Edge	3.5L	TiVCT	FLM(Front Lighting Control Module)			V	V	V		V		V																	
Ford	Edge	3.5L	TiVCT	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Edge	3.5L	TiVCT	HUD(Head Up Display)			V	V	V		V		V																	
Ford	Edge	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Edge	3.5L	TiVCT	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Edge	3.5L	TiVCT	LTM(Liftgate/Trunk Module)			V	V	V																					
Ford	Edge	3.5L	TiVCT	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Edge	3.5L	TiVCT	PAM(Parking Aid Module)			V	V	V	V	V		V																	
Ford	Edge	3.5L	TiVCT	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Edge	3.5L	TiVCT	RFA(Remote Function Actuator)			V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Edge	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)			V	V	V		V																			
Ford	Edge	3.5L	TiVCT	TPM(Tire Pressure Monitor)			V	V	V		V		V																	
Ford	Edge	3.5L	TiVCT	SCCM(Steering Column Control Module)			V	V	V	V	V																			
Ford	Edge	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V																			
Ford	Edge	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Ford	Edge	3.5L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Edge	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.7L	TiVCT	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Edge	3.7L	TiVCT	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Edge	3.7L	TiVCT	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Edge	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Edge	3.7L	TiVCT	BCM(Body Control Module)			V	V	V	V	V		V											V						
Ford	Edge	3.7L	TiVCT	C-CM(Cruise Control Module)			V	V	V		V		V																	
Ford	Edge	3.7L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V																				
Ford	Edge	3.7L	TiVCT	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)			V	V	V	V	V		V																	
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Edge	3.7L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	Edge	3.7L	TiVCT	FLM(Front Lighting Control Module)			V	V	V		V		V																	
Ford	Edge	3.7L	TiVCT	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Edge	3.7L	TiVCT	HUD(Head Up Display)			V	V	V		V		V																	
Ford	Edge	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Edge	3.7L	TiVCT	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Edge	3.7L	TiVCT	LTM(Liftgate/Trunk Module)			V	V	V																					
Ford	Edge	3.7L	TiVCT	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Edge	3.7L	TiVCT	PAM(Parking Aid Module)			V	V	V	V	V		V																	
Ford	Edge	3.7L	TiVCT	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Edge	3.7L	TiVCT	RFA(Remote Function Actuator)			V	V	V	V	V		V																	
Ford	Edge	3.7L	TiVCT	RLCM-A(Rear Lighting Control Module A)			V	V	V		V																			
Ford	Edge	3.7L	TiVCT	TPM(Tire Pressure Monitor)			V	V	V		V		V																	
Ford	Edge	3.7L	TiVCT	SCCM(Steering Column Control Module)			V	V	V	V	V																			
Ford	Edge	3.7L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V																			
Ford	Edge	3.7L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Ford	Edge	3.7L	TiVCT	TBM(Tracking And Blocking Module)			V	V	V																					
Ford	Edge	3.7L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Escape	Up to 2004	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Escape	Up to 2004	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Escape	Up to 2004	Immobilizer																											
Ford	Escape	Up to 2004	ABS(Anti-Lock Brake System)				V	V	V														V							
Ford	Escape	Up to 2004	RCM(Restraint Control Module)				V	V	V	V													V							
Ford	Escape	Up to 2004	GEM(Generic Electronic Module)				V	V	V	V													V							
Ford	Escape	From 2004	SYSTEM SEARCH																											
Ford	Escape	From 2004	PCM(PowerTrain Control Module)				V	V	V			V	V	V																
Ford	Escape	From 2004	PATS(Passive Anti Theft System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)				V	V	V	V																				
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)				V	V																						
Ford	Escape	From 2004	RCM(Restraint Control Module)				V	V	V	V																				
Ford	Escape	From 2004	IC(Instrument cluster)				V	V	V				V																	
Ford	Escape	From 2004	GEM(Generic Electronic Module)				V	V	V	V																				
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V	V	V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V	V	V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)			V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V	V	V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V		V																			
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V																			
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)			V	V	V		V																			
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)			V	V	V	V	V																			
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)			V	V	V	V	V																			
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)			V	V	V	V	V		V																	
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)			V	V	V							V	V	V	V											
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)			V	V	V				V																	
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)			V	V					V																	
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)			V	V	V	V			V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)			V	V	V				V																	
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)			V	V					V																	
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)			V	V	V				V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)			V	V	V				V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)			V	V					V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)			V	V	V	V			V																	
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)			V	V	V	V																				
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Excursion	GASOLINE	SYSTEM SEARCH																											
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)				V	V	V	V					V	V	V	V	V											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)				V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Excursion	GASOLINE	ABS(Anti-Lock Brake System)				V		V	V											V									
Ford	Excursion	GASOLINE	CSM(Central Security Module)				V		V	V																				
Ford	Excursion	GASOLINE	DSM(Driver's Seat Module)				V		V	V																				
Ford	Excursion	GASOLINE	EATC(Electronic Automatic Temperature Control)				V		V																					
Ford	Excursion	GASOLINE	ECS(Electronic Crash Sensor)				V		V																					
Ford	Excursion	GASOLINE	GEM(Generic Electronic Module)				V		V																					
Ford	Excursion	GASOLINE	HEC(Hybrid Electrical Cluster)				V	V	V	V																				
Ford	Excursion	GASOLINE	OTC(Overhead Trip Computer)				V		V																					
Ford	Excursion	GASOLINE	PAM(Parking Aid Module)				V		V																					
Ford	Excursion	GASOLINE	PATS(Passive Anti Theft System)				V	V	V	V																				
Ford	Excursion	GASOLINE	TCM(Transmission Control Module)				V	V	V				V	V																
Ford	Excursion	GASOLINE	VSM(Vehicle Security Module)				V		V																					
Ford	Excursion	DIESEL	SYSTEM SEARCH																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)				V	V	V	V					V	V	V	V	V											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)				V	V	V		V	V	V	V	V															
Ford	Excursion	DIESEL	ABS(Anti-Lock Brake System)				V		V	V											V									
Ford	Excursion	DIESEL	CSM(Central Security Module)				V		V	V																				
Ford	Excursion	DIESEL	DSM(Driver's Seat Module)				V		V	V																				
Ford	Excursion	DIESEL	EATC(Electronic Automatic Temperature Control)				V		V																					
Ford	Excursion	DIESEL	ECS(Electronic Crash Sensor)				V		V																					
Ford	Excursion	DIESEL	GEM(Generic Electronic Module)				V		V																					
Ford	Excursion	DIESEL	HEC(Hybrid Electrical Cluster)				V	V	V	V																				
Ford	Excursion	DIESEL	OTC(Overhead Trip Computer)				V		V																					
Ford	Excursion	DIESEL	PAM(Parking Aid Module)				V		V																					
Ford	Excursion	DIESEL	PATS(Passive Anti Theft System)				V	V	V	V																				
Ford	Excursion	DIESEL	TCM(Transmission Control Module)				V	V	V				V	V																
Ford	Excursion	DIESEL	VSM(Vehicle Security Module)				V		V																					
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)		V	V	V	V																				
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V															
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)		V	V	V														V							
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)		V	V	V				V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V													V							
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)		V	V	V				V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PRB(Power Running Board)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)		V		V																					
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCU(Audio Rear Control Unit)		V	V	V	V																				
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	TCM(Transmission Control Module)		V	V	V							V	V	V	V											
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VDM(Vehicle Dynamic Module)		V	V	V	V			V																	V
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VSM(Vehicle Security Module)		V	V	V	V			V											V						
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)		V	V	V	V																				
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V															
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)		V	V	V														V							
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)		V	V	V				V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V													V							
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GPSM(Global Positioning System Module)		V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)		V	V	V				V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PRB(Power Running Board)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)		V		V																					
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCU(Audio Rear Control Unit)		V	V	V	V																				
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TBC(Trailer Brake Control Module)		V	V	V				V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCCM(Transfer Case Control Module)		V	V	V	V	V		V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCM(Transmission Control Module)		V	V	V							V	V	V	V											
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	VDM(Vehicle Dynamic Module)		V	V	V	V			V																	V
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)			V	V	V	V																				
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V												
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	ExpeditionExpedition EL	5.4L	2V	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	2V	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	2V	GEM(Generic Electronic Module)			V	V	V	V													V							
Ford	ExpeditionExpedition EL	5.4L	2V	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	2V	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	2V	PAM(Parking Aid Module)			V		V																					
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)			V	V	V																					
Ford	ExpeditionExpedition EL	5.4L	2V	VDM(Vehicle Dynamic Module)			V	V	V																					
Ford	ExpeditionExpedition EL	5.4L	2V	RIM(Remote Immobilizer Module)			V	V	V	V													V							
Ford	ExpeditionExpedition EL	5.4L	2V	VSM(Vehicle Security Module)			V	V	V	V			V											V						
Ford	ExpeditionExpedition EL	4.6L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)			V	V	V	V																				
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	ExpeditionExpedition EL	4.6L	2V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	ExpeditionExpedition EL	4.6L	2V	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	4.6L	2V	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)			V	V	V				V																	
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V													V							
Ford	ExpeditionExpedition EL	4.6L	2V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	ExpeditionExpedition EL	4.6L	2V	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	4.6L	2V	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	4.6L	2V	LTM(Liftgate/Trunk Module)			V	V	V				V																	
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)			V	V	V				V																	
Ford	ExpeditionExpedition EL	4.6L	2V	PRB(Power Running Board)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)			V		V																					
Ford	ExpeditionExpedition EL	4.6L	2V	RCU(Audio Rear Control Unit)			V	V	V	V																				
Ford	ExpeditionExpedition EL	4.6L	2V	RETM(Rear Entertainment Module)			V	V	V				V																	
Ford	ExpeditionExpedition EL	4.6L	2V	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	4.6L	2V	TCM(Transmission Control Module)			V	V	V							V	V	V	V											
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)			V	V	V	V			V																	V
Ford	ExpeditionExpedition EL	4.6L	2V	4X4(4x4 Control Module)			V	V	V	V			V																	
Ford	ExpeditionExpedition EL	4.6L	2V	RIM(Remote Immobilizer Module)			V	V	V	V													V							
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)			V		V																					
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)			V	V	V																					
Ford	ExpeditionExpedition EL	4.6L	2V	VSM(Vehicle Security Module)			V	V	V	V			V											V						
Ford	Explorer	2015 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Explorer	2015 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)		V	V	V	V	V		V								V									
Ford	Explorer	2015 MY	3.5L	TiVCT	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	BCM(Body Control Module)		V	V	V	V	V		V											V						
Ford	Explorer	2015 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	C-CM(Cruise Control Module)		V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2015 MY	3.5L	TiVCT	CLM(Column Lock Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	PAM(Parking Aid Module)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)		V	V	V		V																			
Ford	Explorer	2015 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)		V	V	V	V	V																			
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)		V	V	V		V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)		V	V	V		V				V	V	V	V	V											
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)		V	V	V	V	V										V									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)		V	V	V				V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)		V	V	V	V	V		V											V						
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)		V	V	V		V																			
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)		V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)		V	V	V	V			V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)		V	V	V		V																			
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)		V	V	V		V																			
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)		V	V	V		V																			
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)		V	V	V		V																			
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)		V	V	V	V	V																			
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Explorer	2014 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)		V	V	V	V	V		V								V									
Ford	Explorer	2014 MY	3.5L	TiVCT	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	BCM(Body Control Module)		V	V	V	V	V		V											V						
Ford	Explorer	2014 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	C-CM(Cruise Control Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	CLM(Column Lock Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2014 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	PAM(Parking Aid Module)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)		V	V	V		V																			
Ford	Explorer	2014 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)		V	V	V	V	V																			
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)		V	V	V		V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)		V	V	V		V				V	V	V	V	V											
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)		V	V	V	V	V										V									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)		V	V	V				V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)		V	V	V	V	V		V											V						
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)		V	V	V		V																			
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)		V	V	V	V			V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)		V	V	V		V																			
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)		V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)		V	V	V		V																			
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)		V	V	V		V																			
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)		V	V	V		V																			
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)		V	V	V	V	V																			
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Explorer	2013 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)		V	V	V	V	V		V								V									
Ford	Explorer	2013 MY	3.5L	TiVCT	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	BCM(Body Control Module)		V	V	V	V	V		V											V						
Ford	Explorer	2013 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	C-CM(Cruise Control Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	CLM(Column Lock Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	PAM(Parking Aid Module)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)		V	V	V		V																			
Ford	Explorer	2013 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)		V	V	V	V	V																			
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)		V	V	V		V		V																	
Ford	Explorer	2013 MY	3.5L	TiVCT	PATS(Passive Anti Theft System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)		V	V	V		V				V	V	V	V	V											
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)		V	V	V	V	V										V									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)		V	V	V				V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)		V	V	V	V	V		V											V						
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)		V	V	V		V																			
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)		V	V	V	V			V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)		V	V	V		V																			
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)		V	V	V		V																			
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)		V	V	V		V																			
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)		V	V	V		V																			
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)		V	V	V	V	V																			
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2012 MY	3.5L	TiVCT	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Explorer	2012 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)		V	V	V	V	V		V								V									
Ford	Explorer	2012 MY	3.5L	TiVCT	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	BCM(Body Control Module)		V	V	V	V	V		V											V						
Ford	Explorer	2012 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	C-CM(Cruise Control Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	CLM(Column Lock Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	PAM(Parking Aid Module)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)		V	V	V		V																			
Ford	Explorer	2012 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)		V	V	V	V	V																			
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)		V	V	V		V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)		V	V	V		V				V	V	V	V	V											
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)		V	V	V	V	V										V									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)		V	V	V				V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)		V	V	V	V	V		V											V						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)		V	V	V		V																			
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)		V	V	V	V			V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)		V	V	V		V																			
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)		V	V	V		V																			
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)		V	V	V		V																			
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)		V	V	V		V																			
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)		V	V	V	V	V																			
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Explorer	2011 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)		V	V	V	V	V		V								V									
Ford	Explorer	2011 MY	3.5L	TiVCT	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	BCM(Body Control Module)		V	V	V	V	V		V											V						
Ford	Explorer	2011 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	C-CM(Cruise Control Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	CLM(Column Lock Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	DSM(Driver's Seat Module)		V	V	V	V			V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	PAM(Parking Aid Module)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)		V	V	V		V																			
Ford	Explorer	2011 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)		V	V	V	V	V																			
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)		V	V	V		V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)		V	V	V		V				V	V	V	V	V											
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)		V	V	V	V	V										V									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)		V	V	V				V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)		V	V	V	V	V		V											V						
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)		V	V	V		V																			
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)		V	V	V	V			V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)		V	V	V		V																			
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)		V	V	V		V																			
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)		V	V	V		V																			
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)		V	V	V		V																			
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)		V	V	V	V	V																			
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Explorer	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2010 MY	4.0L	2V	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Explorer	2010 MY	4.0L	2V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer	2010 MY	4.0L	2V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)		V	V	V	V											V	V								
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V			V																	
Ford	Explorer	2010 MY	4.0L	2V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V			V											V						
Ford	Explorer	2010 MY	4.0L	2V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer	2010 MY	4.0L	2V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer	2010 MY	4.0L	2V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer	2010 MY	4.0L	2V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2010 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2010 MY	4.6L	3V	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer	2010 MY	4.6L	3V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer	2010 MY	4.6L	3V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer	2010 MY	4.6L	3V	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V			V																	
Ford	Explorer	2010 MY	4.6L	3V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V			V											V						
Ford	Explorer	2010 MY	4.6L	3V	IC(Instrument Cluster)		V	V	V				V																	
Ford	Explorer	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer	2010 MY	4.6L	3V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer	2010 MY	4.6L	3V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer	2010 MY	4.6L	3V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2009 MY	4.0L	2V	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Explorer	2009 MY	4.0L	2V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer	2009 MY	4.0L	2V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)		V	V	V	V											V	V								
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.0L	2V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V			V											V						
Ford	Explorer	2009 MY	4.0L	2V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer	2009 MY	4.0L	2V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer	2009 MY	4.0L	2V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.0L	2V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2009 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2009 MY	4.6L	3V	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer	2009 MY	4.6L	3V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer	2009 MY	4.6L	3V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer	2009 MY	4.6L	3V	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.6L	3V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V			V											V						
Ford	Explorer	2009 MY	4.6L	3V	IC(Instrument Cluster)		V	V	V				V																	
Ford	Explorer	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer	2009 MY	4.6L	3V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer	2009 MY	4.6L	3V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.6L	3V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.0L	2V	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Explorer	2008 MY	4.0L	2V	TCM(Transmission Control Module)		V	V	V				V			V	V	V	V											
Ford	Explorer	2008 MY	4.0L	2V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer	2008 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer	2008 MY	4.0L	2V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.0L	2V	GEM(Generic Electronic Module)		V	V	V	V			V											V						
Ford	Explorer	2008 MY	4.0L	2V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer	2008 MY	4.0L	2V	PAM(Parking Aid Module)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.0L	2V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.0L	2V	RCM(Restraint Control Module)		V	V	V	V																				
Ford	Explorer	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.6L	3V	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer	2008 MY	4.6L	3V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer	2008 MY	4.6L	3V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2008 MY	4.6L	3V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer	2008 MY	4.6L	3V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.6L	3V	GEM(Generic Electronic Module)		V	V	V	V			V											V						
Ford	Explorer	2008 MY	4.6L	3V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer	2008 MY	4.6L	3V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer	2008 MY	4.6L	3V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.6L	3V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.0L	2V	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Explorer	2007 MY	4.0L	2V	TCM(Transmission Control Module)		V	V	V				V			V	V	V	V											
Ford	Explorer	2007 MY	4.0L	2V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer	2007 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer	2007 MY	4.0L	2V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.0L	2V	GEM(Generic Electronic Module)		V	V	V	V			V											V						
Ford	Explorer	2007 MY	4.0L	2V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer	2007 MY	4.0L	2V	PAM(Parking Aid Module)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.0L	2V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.0L	2V	RCM(Restraint Control Module)		V	V	V	V																				
Ford	Explorer	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.6L	3V	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer	2007 MY	4.6L	3V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer	2007 MY	4.6L	3V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer	2007 MY	4.6L	3V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer	2007 MY	4.6L	3V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.6L	3V	GEM(Generic Electronic Module)		V	V	V	V			V											V						
Ford	Explorer	2007 MY	4.6L	3V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)		V	V	V				V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2007 MY	4.6L	3V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer	2007 MY	4.6L	3V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.6L	3V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.0L	2V	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Explorer	2006 MY	4.0L	2V	TCM(Transmission Control Module)		V	V	V				V			V	V	V	V											
Ford	Explorer	2006 MY	4.0L	2V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer	2006 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer	2006 MY	4.0L	2V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.0L	2V	GEM(Generic Electronic Module)		V	V	V	V			V											V						
Ford	Explorer	2006 MY	4.0L	2V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer	2006 MY	4.0L	2V	PAM(Parking Aid Module)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.0L	2V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.0L	2V	RCM(Restraint Control Module)		V	V	V	V																				
Ford	Explorer	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.6L	3V	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer	2006 MY	4.6L	3V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer	2006 MY	4.6L	3V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer	2006 MY	4.6L	3V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer	2006 MY	4.6L	3V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.6L	3V	GEM(Generic Electronic Module)		V	V	V	V			V											V						
Ford	Explorer	2006 MY	4.6L	3V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer	2006 MY	4.6L	3V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer	2006 MY	4.6L	3V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.6L	3V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer	2005 MY	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)				V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Explorer	2005 MY	ABS(Anti-Lock Brake System)				V	V	V																					
Ford	Explorer	2005 MY	PAM(Parking Aid Module)				V	V	V														V							
Ford	Explorer	2005 MY	4X4(4x4 Control Module)				V		V																					
Ford	Explorer	2005 MY	HEC(Hybrid Electrical Cluster)				V	V	V	V																				
Ford	Explorer	2005 MY	RCM(Restraint Control Module)				V		V																					
Ford	Explorer	2005 MY	VSM(Vehicle Security Module)				V		V																					
Ford	Explorer	2004 MY	SYSTEM SEARCH																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)				V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Explorer	2004 MY	ABS(Anti-Lock Brake System)				V	V	V																					
Ford	Explorer	2004 MY	PAM(Parking Aid Module)				V	V	V														V							
Ford	Explorer	2004 MY	4X4(4x4 Control Module)				V		V																					
Ford	Explorer	2004 MY	HEC(Hybrid Electrical Cluster)				V	V	V	V																				
Ford	Explorer	2004 MY	RCM(Restraint Control Module)				V		V																					
Ford	Explorer	2004 MY	VSM(Vehicle Security Module)				V		V																					
Ford	Explorer	2003 MY	SYSTEM SEARCH																											
Ford	Explorer	2003 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Explorer	2003 MY	ABS(Anti-Lock Brake System)				V	V	V																					
Ford	Explorer	2003 MY	PAM(Parking Aid Module)				V	V	V														V							
Ford	Explorer	2003 MY	4X4(4x4 Control Module)				V		V																					
Ford	Explorer	2003 MY	HEC(Hybrid Electrical Cluster)				V	V	V	V																				
Ford	Explorer	2003 MY	RCM(Restraint Control Module)				V		V																					
Ford	Explorer	2003 MY	VSM(Vehicle Security Module)				V		V																					
Ford	Explorer	2002 MY	SYSTEM SEARCH																											
Ford	Explorer	2002 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Explorer	2002 MY	ABS(Anti-Lock Brake System)				V	V	V																					
Ford	Explorer	2002 MY	PAM(Parking Aid Module)				V	V	V														V							
Ford	Explorer	2002 MY	4X4(4x4 Control Module)				V		V																					
Ford	Explorer	2002 MY	HEC(Hybrid Electrical Cluster)				V	V	V	V																				
Ford	Explorer	2002 MY	RCM(Restraint Control Module)				V		V																					
Ford	Explorer	2002 MY	VSM(Vehicle Security Module)				V		V																					
Ford	Explorer	2001 MY	SYSTEM SEARCH																											
Ford	Explorer	2001 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Explorer	2001 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Ford	Explorer	2001 MY	RCM(Restraint Control Module)				V	V	V	V													V							
Ford	Explorer	2001 MY	RIM(Remote Immobilizer Module)				V	V	V	V													V							

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer	2001 MY	GEM(Generic Electronic Module)				V	V	V	V													V							
Ford	Explorer	2001 MY	PAM(Parking Aid Module)				V	V	V														V							
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)				V	V	V	V																				
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)				V	V	V																					
Ford	Explorer	2000 MY	SYSTEM SEARCH																											
Ford	Explorer	2000 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Explorer	2000 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Ford	Explorer	2000 MY	RCM(Restraint Control Module)				V	V	V	V													V							
Ford	Explorer	2000 MY	RIM(Remote Immobilizer Module)				V	V	V	V													V							
Ford	Explorer	2000 MY	GEM(Generic Electronic Module)				V	V	V	V													V							
Ford	Explorer	2000 MY	PAM(Parking Aid Module)				V	V	V														V							
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)				V	V	V	V																				
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)				V	V	V																					
Ford	Explorer	1999 MY	SYSTEM SEARCH																											
Ford	Explorer	1999 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Explorer	1999 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Ford	Explorer	1999 MY	RCM(Restraint Control Module)				V	V	V	V													V							
Ford	Explorer	1999 MY	RIM(Remote Immobilizer Module)				V	V	V	V													V							
Ford	Explorer	1999 MY	PAM(Parking Aid Module)				V	V	V														V							
Ford	Explorer	1998 MY	SYSTEM SEARCH																											
Ford	Explorer	1998 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Explorer	1998 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Ford	Explorer	1998 MY	RCM(Restraint Control Module)				V	V	V	V													V							
Ford	Explorer	1998 MY	RIM(Remote Immobilizer Module)				V	V	V	V													V							
Ford	Explorer	1997 MY	SYSTEM SEARCH																											
Ford	Explorer	1997 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Explorer	1997 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Ford	Explorer	1997 MY	RCM(Restraint Control Module)				V	V	V														V							
Ford	Explorer	1997 MY	RIM(Remote Immobilizer Module)				V	V	V	V													V							
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Explorer SportTrac	2010 MY	4.0L	2V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer SportTrac	2010 MY	4.0L	2V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)		V	V	V	V											V	V								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)		V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer SportTrac	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V			V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V			V											V						
Ford	Explorer SportTrac	2010 MY	4.0L	2V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer SportTrac	2010 MY	4.6L	3V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer SportTrac	2010 MY	4.6L	3V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V			V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V			V											V						
Ford	Explorer SportTrac	2010 MY	4.6L	3V	IC(Instrument Cluster)		V	V	V				V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Explorer SportTrac	2009 MY	4.0L	2V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer SportTrac	2009 MY	4.0L	2V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)		V	V	V	V											V	V								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)		V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer SportTrac	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V			V											V						
Ford	Explorer SportTrac	2009 MY	4.0L	2V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer SportTrac	2009 MY	4.6L	3V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer SportTrac	2009 MY	4.6L	3V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V			V											V						
Ford	Explorer SportTrac	2009 MY	4.6L	3V	IC(Instrument Cluster)		V	V	V				V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PCM(Powertrain Control Module)		V	V	V				V																	
Ford	Explorer SportTrac	2008 MY	4.0L	2V	TCM(Transmission Control Module)		V	V	V				V			V	V	V	V											
Ford	Explorer SportTrac	2008 MY	4.0L	2V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer SportTrac	2008 MY	4.0L	2V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.0L	2V	GEM(Generic Electronic Module)		V	V	V	V			V											V						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer SportTrac	2008 MY	4.0L	2V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PAM(Parking Aid Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RCM(Restraint Control Module)		V	V	V	V																				
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer SportTrac	2008 MY	4.6L	3V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer SportTrac	2008 MY	4.6L	3V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer SportTrac	2008 MY	4.6L	3V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.6L	3V	GEM(Generic Electronic Module)		V	V	V	V			V											V						
Ford	Explorer SportTrac	2008 MY	4.6L	3V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PCM(Powertrain Control Module)		V	V	V				V																	
Ford	Explorer SportTrac	2007 MY	4.0L	2V	TCM(Transmission Control Module)		V	V	V				V			V	V	V	V											
Ford	Explorer SportTrac	2007 MY	4.0L	2V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer SportTrac	2007 MY	4.0L	2V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.0L	2V	GEM(Generic Electronic Module)		V	V	V	V			V											V						
Ford	Explorer SportTrac	2007 MY	4.0L	2V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PAM(Parking Aid Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RCM(Restraint Control Module)		V	V	V	V																				
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)		V	V	V				V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer SportTrac	2007 MY	4.6L	3V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer SportTrac	2007 MY	4.6L	3V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer SportTrac	2007 MY	4.6L	3V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.6L	3V	GEM(Generic Electronic Module)		V	V	V	V			V											V						
Ford	Explorer SportTrac	2007 MY	4.6L	3V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PCM(Powertrain Control Module)		V	V	V				V																	
Ford	Explorer SportTrac	2006 MY	4.0L	2V	TCM(Transmission Control Module)		V	V	V				V			V	V	V	V											
Ford	Explorer SportTrac	2006 MY	4.0L	2V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer SportTrac	2006 MY	4.0L	2V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.0L	2V	GEM(Generic Electronic Module)		V	V	V	V			V											V						
Ford	Explorer SportTrac	2006 MY	4.0L	2V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PAM(Parking Aid Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RCM(Restraint Control Module)		V	V	V	V																				
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Explorer SportTrac	2006 MY	4.6L	3V	TCM(Transmission Control Module)		V	V	V				V	V		V	V	V	V											
Ford	Explorer SportTrac	2006 MY	4.6L	3V	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ACM(Audio Control Module)		V	V	V				V																	
Ford	Explorer SportTrac	2006 MY	4.6L	3V	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.6L	3V	GEM(Generic Electronic Module)		V	V	V	V			V											V						
Ford	Explorer SportTrac	2006 MY	4.6L	3V	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PAM(Parking Aid Module)		V	V	V				V																	
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PRB(Power Running Board)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	E-Series	5.4L	2V	2004 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)		V	V	V	V					V	V	V	V	V											
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)		V		V	V											V									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)		V	V	V																					
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)		V	V	V	V																				
Ford	E-Series	5.4L	2V	2004 ~	RAP(Remote Anti-Theft/Personality Module)		V	V	V	V														V	V	V	V			
Ford	E-Series	5.4L	2V	2004 ~	RCM(Restraint Control Module)		V	V	V	V																				
Ford	E-Series	5.4L	2V	2004 ~	PAM(Parking Aid Module)		V		V	V																				
Ford	E-Series	5.4L	2V	2004 ~	VSM(Vehicle Security Module)		V	V	V	V			V																	
Ford	E-Series	5.4L	2V	2009 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	E-Series	5.4L	2V	2009 ~	ABS(Anti-Lock Brake System)		V	V	V	V											V									
Ford	E-Series	5.4L	2V	2009 ~	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	E-Series	5.4L	2V	2009 ~	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	E-Series	5.4L	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Ford	E-Series	5.4L	2V	2009 ~	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	E-Series	5.4L	2V	2009 ~	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	E-Series	5.4L	2V	2009 ~	PAM(Parking Aid Module)		V	V	V	V			V																	
Ford	E-Series	5.4L	2V	2009 ~	RCM(Restraint Control Module)		V	V	V		V																			
Ford	E-Series	5.4L	2V	2009 ~	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	E-Series	5.4L	2V	2009 ~	TBC(Trailer Brake Control Module)		V	V	V				V																	
Ford	E-Series	5.4L	2V	2009 ~	TCM(Transmission Control Module)		V	V	V																					
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V	V	V		V											V						
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V	V	V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)			V	V	V	V	V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)			V	V	V																					
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)			V	V	V	V	V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)			V	V	V				V																	
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)			V	V	V		V		V																	
Ford	F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																										
Ford	F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)			V	V	V	V	V		V											V						
Ford	F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)			V	V	V	V	V		V																	
Ford	F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)			V	V	V	V	V		V																	
Ford	F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)			V	V	V																					
Ford	F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)			V	V	V	V	V		V																	
Ford	F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Ford	F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)			V	V	V				V																	
Ford	F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)			V	V	V		V		V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Ford	F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)		V	V	V				V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)		V	V	V				V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)		V	V	V	V			V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V			V											V						
Ford	F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)		V	V	V	V			V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)		V	V	V	V	V																			
Ford	F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)		V	V	V	V			V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)		V	V	V				V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)		V	V	V	V	V		V																	
Ford	F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)		V	V	V	V	V		V	V		V	V	V	V											
Ford	F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)		V	V	V		V		V																	
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)		V	V	V	V					V	V	V	V	V											
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)		V	V	V														V							
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)		V		V	V																				
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)		V	V	V	V													V							
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)		V	V	V	V													V							
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)		V		V	V																				
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)		V		V	V																				
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)		V		V	V																				
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)		V		V	V																				
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)		V		V																					
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)		V	V	V	V														V	V	V	V			
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)		V		V	V																				
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	F150	4.6L(BETA)	3V	SYSTEM SEARCH																										
Ford	F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Ford	F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	F150	4.6L(BETA)	3V	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Ford	F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Ford	F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)			V	V	V				V																	
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	F150	4.6L(BETA)	3V	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)			V	V	V	V			V																	
Ford	F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	F150	4.6L(BETA)	3V	PAM(Parking Aid Module)			V	V	V	V	V																			
Ford	F150	4.6L(BETA)	3V	PRB(Power Running Board)			V	V	V	V			V																	
Ford	F150	4.6L(BETA)	3V	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)			V	V	V				V																	
Ford	F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)			V	V	V	V	V		V																	
Ford	F150	4.6L(BETA)	3V	TCM(Transmission Control Module)			V	V	V	V	V		V	V		V	V	V	V											
Ford	F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	F150	5.0L	TiVCT	PCM(Powertrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Ford	F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	F150	5.0L	TiVCT	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Ford	F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Ford	F150	5.0L	TiVCT	DSM(Driver's Seat Module)			V	V	V				V																	
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	F150	5.0L	TiVCT	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	F150	5.0L	TiVCT	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	F150	5.0L	TiVCT	IC(Instrument Cluster)			V	V	V	V	V		V																	
Ford	F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)			V	V	V	V			V																	
Ford	F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)			V	V	V	V	V																			
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	PRB(Power Running Board)			V	V	V	V			V																	
Ford	F150	5.0L	TiVCT	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	RTM(Radio Transceiver Module)			V	V	V		V		V																	
Ford	F150	5.0L	TiVCT	SCCM(Steering Column Control Module)			V	V	V	V	V		V																	
Ford	F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)			V	V	V				V																	
Ford	F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)			V	V	V	V	V		V																	
Ford	F150	5.0L	TiVCT	TCM(Transmission Control Module)			V	V	V	V	V		V	V		V	V	V	V											
Ford	F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)			V	V	V		V		V																	
Ford	F150	5.4L	3V	2009 ~	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V															
Ford	F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	F150	5.4L	3V	2009 ~	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)		V	V	V	V			V																	
Ford	F150	5.4L	3V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V			V											V						
Ford	F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	F150	5.4L	3V	2009 ~	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)		V	V	V	V			V																	
Ford	F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)		V	V	V	V	V																			
Ford	F150	5.4L	3V	2009 ~	PRB(Power Running Board)		V	V	V				V																	
Ford	F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)		V	V	V				V																	
Ford	F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)		V	V	V	V	V		V																	
Ford	F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)		V	V	V	V	V		V	V		V	V	V	V											
Ford	F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)		V	V	V		V		V																	
Ford	F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)		V	V	V	V					V	V	V	V	V											
Ford	F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)		V	V	V														V							
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)		V	V	V	V			V								V	V								
Ford	F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)		V		V	V																				
Ford	F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)		V	V	V	V													V							
Ford	F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)		V	V	V	V													V							
Ford	F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)		V		V	V																				
Ford	F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)		V		V	V																				
Ford	F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)		V	V	V	V			V																	
Ford	F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)		V		V	V																				
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)		V		V	V																				
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)		V		V																					
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)		V	V	V	V														V	V	V	V			
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)		V		V	V																				
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)		V	V	V	V																				
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)		V	V	V																					
Ford	F150	6.2L(BETA)	2V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)			V	V	V	V	V				V															
Ford	F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	F150	6.2L(BETA)	2V	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Ford	F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)			V	V	V				V																	
Ford	F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)			V	V	V																					
Ford	F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Ford	F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	F150	6.2L(BETA)	2V	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)			V	V	V	V			V																	
Ford	F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	F150	6.2L(BETA)	2V	PAM(Parking Aid Module)			V	V	V	V	V		V																	
Ford	F150	6.2L(BETA)	2V	PRB(Power Running Board)			V	V	V				V																	
Ford	F150	6.2L(BETA)	2V	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)			V	V	V				V																	
Ford	F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)			V	V	V	V	V																			
Ford	F150	6.2L(BETA)	2V	TCM(Transmission Control Module)			V	V	V	V	V		V	V		V	V	V	V											
Ford	F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)			V	V	V		V		V																	
Ford	F150	Other	2004 ~ 2008	SYSTEM SEARCH																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)			V	V	V	V					V	V	V	V	V											
Ford	F150	Other	2004 ~ 2008	4X4(4x4 Control Module)			V	V	V	V			V																	
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)			V	V	V	V													V							
Ford	F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)			V	V	V	V													V							
Ford	F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)			V		V	V																				
Ford	F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)			V		V	V																				
Ford	F150	Other	2004 ~ 2008	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	F150	Other	2004 ~ 2008	PAM(Parking Aid Module)			V		V	V																				
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)			V		V	V																				
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)			V		V																					
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)			V	V	V	V														V	V	V	V			
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)			V		V	V																				
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)			V	V	V	V																				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)			V	V	V																					
Ford	F250	7.3L	SYSTEM SEARCH																											
Ford	F250	7.3L	PCM(PowerTrain Control Module)				V		V																					
Ford	F250	7.3L	ABS(Anti-Lock Brake System)				V	V	V	V																				
Ford	F250	7.3L	ECS(Electronic Crash Sensor)				V	V	V																					
Ford	F250	7.3L	GEM(Generic Electronic Module)				V	V																						
Ford	F250	6.2L	SYSTEM SEARCH																											
Ford	F250	6.2L	PCM(Powertrain Control Module)				V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	F250	6.2L	ABS(Anti-Lock Brake System)				V	V	V	V	V		V								V	V								
Ford	F250	6.2L	ACM(Audio Control Module)				V	V	V		V		V																	
Ford	F250	6.2L	APIM(Accessory Protocol Control Module)				V	V	V		V		V																	
Ford	F250	6.2L	BCMii(Body Control Module)				V	V	V		V		V																	
Ford	F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)				V	V	V	V			V																	
Ford	F250	6.2L	DSM(Driver Seat Module)				V	V	V	V			V																	
Ford	F250	6.2L	GPSM(Global Positioning System Module)				V	V	V		V																			
Ford	F250	6.2L	HVAC(Heating Ventilation Air Conditioning)				V	V	V	V	V		V																	
Ford	F250	6.2L	IPC(Instrument Panel Control Module)				V	V	V	V	V		V																	
Ford	F250	6.2L	PAM(Parking Aid Module)				V	V	V		V																			
Ford	F250	6.2L	RCM(Restraint Control Module)				V	V	V		V																			
Ford	F250	6.2L	SCCM(Streering Colume Control Module)				V	V	V	V	V		V																	
Ford	F250	6.2L	TBC(Trailer Brake Control Module)				V	V	V																					
Ford	F250	6.2L	TCCM(Transfer Case Control Module)				V	V	V	V	V		V																	
Ford	F250	6.2L	TPM(Tire Pressure Monitor)				V	V	V		V		V																	
Ford	F250	6.0L	SYSTEM SEARCH																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)				V	V	V		V	V	V	V	V															
Ford	F250	6.0L	PCM(PowerTrain Control Module)				V	V	V		V																			
Ford	F250	6.0L	PCM(PowerTrain Control Module)				V	V	V	V					V	V	V	V	V											
Ford	F250	6.0L	ABS(Anti-Lock Brake System)				V		V	V											V									
Ford	F250	6.0L	GEM(Generic Electronic Module)				V		V																					
Ford	F250	6.0L	HEC(Hybrid Electrical Cluster)				V	V	V	V																				
Ford	F250	6.0L	OTC(Overhead Trip Computer)				V		V																					
Ford	F250	6.0L	PAM(Parking Aid Module)				V		V																					
Ford	F250	6.0L	PATS(Passive Anti Theft System)				V	V	V	V																				
Ford	F250	6.0L	RCM(Restraint Control Module)				V	V	V																					
Ford	F250	6.0L	TCM(Transmission Control Module)				V		V	V																				
Ford	F250	6.0L	TCM(Transmission Control Module)				V	V	V				V	V																
Ford	F250	6.0L	TCM(Transmission Control Module)				V		V		V																			
Ford	F250	6.0L	VSM(Vehicle Security Module)				V		V																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SYSTEM SEARCH																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM(PowerTrain Control Module)			V	V	V		V	V	V	V																
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4(4x4 Control Module)			V	V	V																					
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS(Anti-Lock Brake System)			V	V	V												V									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM(Auxiliary Heater Control Module)			V	V	V	V																				
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM(Circuit Deactivation Ignition Module)			V	V	V				V																	
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM(Driver's Seat Module)			V	V	V				V																	
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM(Parking Aid Module)			V	V	V				V																	
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM(Restraint Control Module)			V	V	V																					
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM(Rear Entertainment Module)			V	V	V				V																	
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC(Trailer Brake Control Module)			V	V	V				V																	
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM(Transmission Control Module)			V	V	V							V	V	V	V											
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)		V	V	V	V	V		V	V																
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)		V	V	V		V		V	V	V	V	V	V	V											
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)		V	V	V	V			V								V									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)		V	V	V	V	V		V								V	V								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)		V	V	V				V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)		V	V	V	V	V		V											V						
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)		V	V	V				V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)		V	V	V	V	V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)		V	V	V	V			V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)		V	V	V	V	V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)		V	V	V				V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)		V	V	V	V	V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)		V	V	V	V	V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)		V	V	V	V	V		V	V																
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)		V	V	V												V									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)		V	V	V	V	V		V								V	V								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)		V	V	V	V																				
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)		V	V	V				V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)		V	V	V		V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)		V	V	V		V																			
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)		V	V	V	V	V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)		V	V	V				V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)		V	V	V	V	V		V																	
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)		V	V	V		V		V	V	V	V	V	V	V											
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)		V	V	V		V		V																	
Ford	Fiesta	1.4L	DURATEC 16V	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)			V	V	V				V	V	V															
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)			V	V	V																					
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)			V	V	V		V																			
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)			V	V	V	V													V							

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Fiesta	1.4L	DURATEC 16V	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)			V	V	V																					
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)			V	V	V	V			V																	
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Fiesta	1.4L	DURATEC 16V	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Fiesta	1.4L	DURATEC 16V	BCMii(Body Control Module)			V	V	V	V	V		V																	
Ford	Fiesta	1.4L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)			V	V	V		V		V																	
Ford	Fiesta	1.4L	DURATEC 16V	SRM(Speech Recognition Module)			V	V	V		V		V																	
Ford	Fiesta	1.4L	DURATEC 16V	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V		V		V	V																
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V																
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)			V	V	V																					
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V																					
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)			V	V	V		V		V																	
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)			V	V	V		V		V																	
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Fiesta	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)			V	V	V																					
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)			V	V	V		V																			
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)			V	V	V	V													V							

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Fiesta	1.6L	DURATEC	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)			V	V	V																					
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)			V	V	V	V			V																	
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)			V	V	V	V			V																	
Ford	Fiesta	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Fiesta	1.6L	DURATEC	BCMii(Body Control Module)			V	V	V	V	V		V																	
Ford	Fiesta	1.6L	DURATEC	FCDIM(Front Control/Display Interface Module)			V	V	V		V		V																	
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)			V	V	V		V		V																	
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)			V	V	V				V																	
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)			V	V	V				V																	
Ford	Fiesta	1.6L	TiVCT	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V																
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V															
Ford	Fiesta	1.6L	TiVCT	TCM(Transmission Control Module)			V	V	V		V																			
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)			V	V	V	V	V										V									
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.6L	TiVCT	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Fiesta	1.6L	TiVCT	BCM(Body Control Module)			V	V	V	V	V		V																	
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V																			
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V																			
Ford	Fiesta	1.6L	TiVCT	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Fiesta	1.6L	TiVCT	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Fiesta	1.6L	TiVCT	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.6L	TiVCT	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Fiesta	1.6L	TiVCT	RFA(Remote Function Actuator)			V	V	V		V																			
Ford	Fiesta	1.6L	TiVCT	VSM(Vehicle Security Module)			V	V	V	V			V																	
Ford	Fiesta	1.6L	Zetec Rocam	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Fiesta	1.6L	Zetec Rocam	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Fiesta	1.6L	Zetec Rocam	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Fiesta	1.6L	Zetec Rocam	RCM(Restraint Control Module)			V	V	V																					
Ford	Fiesta	1.6L	Zetec Rocam	RKE(Remote Keyless Entry)			V	V	V																					
Ford	Fiesta	1.6L	Zetec Rocam	TCM(Transmission Control Module)			V	V	V						V															
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	SYSTEM SEARCH																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)			V	V	V																					
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)			V	V	V																					
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)			V	V	V	V																				
Ford	Fiesta	2.0L	SYSTEM SEARCH																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)				V	V	V	V	V	V	V	V	V															
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)				V	V	V		V		V																	
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)				V	V	V	V													V							
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)				V	V	V		V																			
Ford	Fiesta	2.0L	ACM(Audio Control Module)				V	V	V																					
Ford	Fiesta	2.0L	EATC(Electronic Automatic Temperature Control)				V	V	V	V			V																	
Ford	Fiesta	2.0L	GEM(Generic Electronic Module)				V	V	V	V																				
Ford	Fiesta	2.0L	IC(Instrument Cluster)				V	V	V	V			V																	
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)				V	V	V				V																	
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)				V	V	V				V																	
Ford	Fiesta	2.0L	RCM(Restraint Control Module)				V	V																						
Ford	Fiesta	2.0L	PATS(Passive Anti Theft System)-BETA																											
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)			V	V	V		V		V	V	V															
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V																					
Ford	Focus	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Focus	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Focus	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Focus	1.6L	ZETEC ROCAM	EATC(Electronic Automatic Temperature Control)			V	V	V	V																				
Ford	Focus	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Focus	1.6L	ZETEC ROCAM	HCM(Headlamp Control Module)			V	V	V																					
Ford	Focus	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)			V	V	V	V																				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Focus	1.6L	ZETEC ROCAM	MC(Message Center)			V	V	V	V																				
Ford	Focus	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V		V																			
Ford	Focus	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)			V	V	V																					
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V												V								
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V											V									
Ford	Focus	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V				V																	
Ford	Focus	1.6L	DURATEC-HE/I4	CSM(Central Security Module)			V	V	V	V													V							
Ford	Focus	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)			V	V	V				V																	
Ford	Focus	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)			V	V	V																					
Ford	Focus	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)			V	V	V	V			V																	
Ford	Focus	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)			V	V	V				V																	
Ford	Focus	1.6L	DURATEC-HE/I4	EPS(Electronic power steering)			V	V	V				V																	
Ford	Focus	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)			V	V	V				V																	
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)			V	V	V	V													V							
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Focus	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)			V	V	V				V																	
Ford	Focus	1.6L	DURATEC-HE/I4	NAV(Navigation System)			V	V	V				V																	
Ford	Focus	1.6L	DURATEC-HE/I4	HEC(Hybrid Electrical Cluster)			V	V	V																					
Ford	Focus	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)			V	V	V				V																	
Ford	Focus	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Focus	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)			V	V	V				V																	
Ford	Focus	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)			V	V	V				V																	
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V														V							
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V																					
Ford	Focus	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)			V	V	V																					
Ford	Focus	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)			V	V	V				V																	
Ford	Focus	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)			V	V	V																					
Ford	Focus	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)			V	V	V																					
Ford	Focus	1.6L	DURATEC-HE/I4	SRM(Speech recognition module)			V	V	V				V																	
Ford	Focus	1.6L	DURATEC-HE/I4	MC(Message Center)			V	V		V													V							
Ford	Focus	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)			V	V	V		V																			
Ford	Focus	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Focus	1.6L	DURATEC VCT	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Focus	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)			V	V	V		V																			
Ford	Focus	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)			V	V	V		V																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Focus	1.6L	DURATEC VCT	BCMii(Body Control Module)			V	V	V		V		V																	
Ford	Focus	1.6L	DURATEC VCT	DDM(Driver's Door Module)			V	V	V		V																			
Ford	Focus	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)			V	V	V		V																			
Ford	Focus	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)			V	V	V		V		V																	
Ford	Focus	1.6L	DURATEC VCT	HCM(Headlamp Control Module)			V	V	V		V		V																	
Ford	Focus	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V																			
Ford	Focus	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)			V	V			V		V																	
Ford	Focus	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)			V	V					V																	
Ford	Focus	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Focus	1.6L	DURATEC VCT	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Focus	1.6L	DURATEC VCT	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Focus	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)			V	V	V		V																			
Ford	Focus	1.6L	DURATEC VCT	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Focus	1.6L	DURATEC VCT	RFA(Remote Function Actuator)			V	V	V		V																			
Ford	Focus	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)			V	V	V		V																			
Ford	Focus	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)			V	V	V		V		V																	
Ford	Focus	1.6L	DURATEC VCT	SRM(Speech Recognition Module)			V	V	V		V																			
Ford	Focus	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)			V	V			V		V																	
Ford	Focus	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)			V	V			V		V																	
Ford	Focus	1.6L	DURATEC VCT	TRM(Trailer Module)			V	V	V		V																			
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V		V		V	V																
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V	V											V									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)			V	V	V				V																	
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)			V	V	V				V																	
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)			V	V	V																					
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)			V	V	V	V			V																	
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)			V	V	V				V																	
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic power steering)			V	V	V				V																	
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)			V	V	V																					
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)			V	V	V				V																	
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)			V	V	V				V																	
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)			V	V	V	V																				
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V				V																	
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)			V	V	V				V																	
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V																					
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)			V	V	V																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)			V	V	V				V																	
Ford	Focus	1.8L	DURATEC HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)			V	V	V			V	V	V																
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V													V							
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Focus	1.8L	DURATEC HE/I4	ACM(Audio control module)			V	V	V				V																	
Ford	Focus	1.8L	DURATEC HE/I4	CDP(Compact Disc Player)			V	V	V				V																	
Ford	Focus	1.8L	DURATEC HE/I4	CSM(Central Security Module)			V	V	V	V													V							
Ford	Focus	1.8L	DURATEC HE/I4	D_DCU(Driver Door Control Unit)			V	V	V	V			V																	
Ford	Focus	1.8L	DURATEC HE/I4	EATC(Electronic Automatic Temperature Control)			V	V	V				V																	
Ford	Focus	1.8L	DURATEC HE/I4	EPS(Electronic power steering)			V	V	V				V																	
Ford	Focus	1.8L	DURATEC HE/I4	GDM(Generic Display Module)			V	V	V				V																	
Ford	Focus	1.8L	DURATEC HE/I4	FFH(Fuel Fired Coolant Heating Module)			V	V	V	V																				
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)			V	V	V	V													V							
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Focus	1.8L	DURATEC HE/I4	IC(Instrument cluster)			V	V	V	V																				
Ford	Focus	1.8L	DURATEC HE/I4	NAV(Navigation System)			V	V	V				V																	
Ford	Focus	1.8L	DURATEC HE/I4	PAM(Parking Aid Module)			V	V	V				V																	
Ford	Focus	1.8L	DURATEC HE/I4	PDM(Passenger's Door Module)			V	V	V				V																	
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)			V	V	V														V							
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)			V	V	V																					
Ford	Focus	1.8L	DURATEC HE/I4	RETM(Rear Entertainment Module)			V	V	V																					
Ford	Focus	1.8L	DURATEC HE/I4	RKE(Remote Keyless Entry)			V	V	V				V																	
Ford	Focus	1.8L	DURATEC HE/I4	SRM(Speech recognition module)			V	V	V				V																	
Ford	Focus	1.8L	DURATEC HE/I4	HCM(Headlamp Control Module)			V	V	V				V																	
Ford	Focus	1.8L	DURATEC HE/I4	HEC(Hybrid Electrical Cluster)			V	V	V																					
Ford	Focus	1.8L	DURATEC HE/I4	MC(Message Center)			V	V		V													V							
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)			V	V																						
Ford	Focus	1.8L	DURATEC HE/I4	TCM(Transmission Control Module)			V	V	V																					
Ford	Focus	2.0L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Focus	2.0L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Focus	2.0L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Focus	2.0L DURATEC HE/I4	~2007	IC(Instrument cluster)			V	V	V	V			V																	
Ford	Focus	2.0L DURATEC HE/I4	~2007	RCM(Restraint Control Module)			V	V	V				V																	
Ford	Focus	2.0L DURATEC HE/I4	2008~	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ABS(Anti-Lock Brake System)			V	V	V				V								V									
Ford	Focus	2.0L DURATEC HE/I4	2008~	ACM(Audio control module)			V	V	V				V																	
Ford	Focus	2.0L DURATEC HE/I4	2008~	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Focus	2.0L DURATEC HE/I4	2008~	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	Focus	2.0L DURATEC HE/I4	2008~	FDIM(Front Display Interface Module)			V	V	V				V																	
Ford	Focus	2.0L DURATEC HE/I4	2008~	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Ford	Focus	2.0L DURATEC HE/I4	2008~	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Focus	2.0L DURATEC HE/I4	2008~	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Ford	Focus	2.0L DURATEC HE/I4	2008~	IC(Instrument cluster)			V	V	V	V			V																	
Ford	Focus	2.0L DURATEC HE/I4	2008~	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	Focus	2.0L DURATEC HE/I4	2008~	RCM(Restraint Control Module)			V	V	V				V																	
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)			V	V	V			V	V	V																
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TCM(Transmission control module)			V	V	V																					
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)			V	V	V	V													V							
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)			V	V	V				V																	
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)			V	V	V				V																	
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CDP(Compact Disc Player)			V	V	V				V																	
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CSM(Central Security Module)			V	V	V	V													V							
Ford	Focus	2.0L DURATEC	2003 ~ 2007	D_DCU(Driver Door Control Unit)			V	V	V	V																				
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EATC(Electronic Automatic Temperature Control)			V	V	V				V																	
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EPS(Electronic power steering)			V	V	V				V																	
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GDM(Generic Display Module)			V	V	V																					
Ford	Focus	2.0L DURATEC	2003 ~ 2007	FFH(Fuel Fired Coolant Heating Module)			V	V	V	V																				
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)			V	V	V	V													V							
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HEC(Hybrid Electrical Cluster)			V	V	V																					
Ford	Focus	2.0L DURATEC	2003 ~ 2007	IC(Instrument cluster)			V	V	V	V			V																	
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)			V	V		V													V							
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)			V	V	V	V																				
Ford	Focus	2.0L DURATEC	2003 ~ 2007	NAV(Navigation System)			V	V	V																					
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PAM(Parking Aid Module)			V	V	V				V																	
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PDM(Passenger's Door Module)			V	V	V				V																	
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RETM(Rear Entertainment Module)			V	V	V																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RKE(Remote Keyless Entry)			V	V	V				V																	
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TBM(Tracking And Blocking Module)			V	V	V																					
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RL_DCU(Rear Left Door Control Unit)			V	V	V																					
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RR_DCU(Rear Right Door Control Unit)			V	V	V																					
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SRM(Speech recognition module)			V	V	V				V																	
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HCM(Headlamp Control Module)			V	V	V																					
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)			V	V	V														V							
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)			V	V	V																					
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SYSTEM SEARCH																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V															
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ABS(Anti-Lock Brake System)			V	V	V	V	V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	BCM(Body Control Module)			V	V	V	V	V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DDM(Driver's Door Module)			V	V	V	V	V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SASM(Steering Angle Sensor Module)			V	V	V		V		V																	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	TCM(Transmission Control Module)			V	V	V		V		V	V																
Ford	Focus	2.0L DIESEL	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PCM(PowerTrain Control Module)			V	V	V	V	V		V	V																
Ford	Focus	2.0L DIESEL	2003 ~ 2008	ABS(Anti-Lock Brake System)			V	V	V	V											V	V								
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CDP(Compact Disc Player)			V	V	V				V																	
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CMR(Camera Module Rear)			V	V	V																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Focus	2.0L DIESEL	2003 ~ 2008	D_DCU(Driver Door Control Unit)			V	V	V	V																				
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EATC(Electronic Automatic Temperature Control)			V	V	V				V																	
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EPS(Electronic power steering)			V	V	V				V																	
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FACM(Fuel Additive Control Module)			V	V	V																					
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FFH(Fuel Fired Coolant Heating Module)			V	V	V				V																	
Ford	Focus	2.0L DIESEL	2003 ~ 2008	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Focus	2.0L DIESEL	2003 ~ 2008	HCM(Headlamp Control Module)			V	V	V				V																	
Ford	Focus	2.0L DIESEL	2003 ~ 2008	IC(Instrument cluster)			V	V	V	V			V																	
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PDM(Passenger's Door Module)			V	V	V																					
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PAM(Parking Aid Module)			V	V	V				V																	
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RCM(Restraint Control Module)			V	V	V																					
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RETM(Rear Entertainment Module)			V	V	V																					
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RKE(Remote Keyless Entry)			V	V	V				V																	
Ford	Focus	2.3L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Focus	2.3L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Focus	2.3L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Focus	2.3L DURATEC HE/I4	~2007	IC(Instrument cluster)			V	V	V	V			V																	
Ford	Focus	2.3L DURATEC HE/I4	~2007	RCM(Restraint Control Module)			V	V	V				V																	
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PCM(PowerTrain Control Module)			V	V	V			V	V	V																
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	TCM(Transmission control module)			V	V	V																					
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	EPS(Electronic power steering)			V	V	V				V																	
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	RCM(Restraint Control Module)			V	V	V																					
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	IC(Instrument cluster)			V	V	V	V																				
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	DDM(Driver's Door Module)			V	V	V				V																	
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PDM(Passenger's Door Module)			V	V	V				V																	
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	MC(Message Center)			V	V	V	V																				
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ACM(Audio control module)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V		V		V	V																
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V	V											V									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V				V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)			V	V	V																					
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D DCU(Driver Door Control Unit)			V	V	V	V			V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)			V	V	V																					
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)			V	V	V	V																				
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V																					
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)			V	V	V																					
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)			V	V			V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)			V	V					V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)			V	V			V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)			V	V			V		V																	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V		V																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V																					
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)			V	V	V																					
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)			V	V	V	V			V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EPS(Electronic Power Steering)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V																					
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)			V	V	V																					
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	NAV(Navigation System)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)			V	V	V																					
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)			V	V	V																					
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SRM(Speech Recognition Module)			V	V	V				V																	
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)			V	V	V																					
Ford	Focus C-MAX	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	BCMii(Body Control Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	DURATEC VCT	DDM(Driver's Door Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	DURATEC VCT	HCM(Headlamp Control Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)			V	V			V		V																	
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)			V	V					V																	
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Focus C-MAX	1.6L	DURATEC VCT	PAM(Parking Aid Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Focus C-MAX	1.6L	DURATEC VCT	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	RFA(Remote Function Actuator)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)			V	V	V		V		V																	
Ford	Focus C-MAX	1.6L	DURATEC VCT	SRM(Speech Recognition Module)			V	V	V		V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)			V	V			V		V																	
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)			V	V			V		V																	
Ford	Focus C-MAX	1.6L	DURATEC VCT	TRM(Trailer Module)			V	V	V		V																			
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V															
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V											V									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V				V																	
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CMR(Camera Module Rear)			V	V	V																					
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CDP(Compact Disc Player)			V	V	V				V																	
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)			V	V	V	V																				
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)			V	V	V				V																	
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPB(Electronic Parking Brake)			V	V	V																					
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPS(Electronic Power Steering)			V	V	V				V																	
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)			V	V	V	V																				
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GDM(Generic Display Module)			V	V	V																					
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	HCM(Headlamp Control Module)			V	V	V				V																	
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	NAV(Navigation System)			V	V	V																					
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PAM(Parking Aid Module)			V	V	V																					
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PDM(Passenger's Door Module)			V	V	V				V																	
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V																					
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RETM(Rear Entertainment Module)			V	V	V																					
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RKE(Remote Keyless Entry)			V	V	V																					
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SRM(Speech Recognition Module)			V	V	V				V																	
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V															
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V											V									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V				V																	
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CDP(Compact Disc Player)			V	V	V				V																	
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CMR(Camera Module Rear)			V	V	V																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)			V	V	V	V																				
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)			V	V	V				V																	
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPB(Electronic Parking Brake)			V	V	V																					
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPS(Electronic Power Steering)			V	V	V				V																	
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)			V	V	V																					
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GDM(Generic Display Module)			V	V	V	V																				
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	HCM(Headlamp Control Module)			V	V	V				V																	
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	NAV(Navigation System)			V	V	V																					
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PAM(Parking Aid Module)			V	V	V																					
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PDM(Passenger's Door Module)			V	V	V				V																	
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V																					
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RETM(Rear Entertainment Module)			V	V	V																					
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RKE(Remote Keyless Entry)			V	V	V																					
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SRM(Speech Recognition Module)			V	V	V				V																	
Ford	Flex	3.5L	4V	SYSTEM SEARCH																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)			V	V	V		V	V	V	V																
Ford	Flex	3.5L	4V	4X4(4x4 Control Module)			V	V	V	V			V																	
Ford	Flex	3.5L	4V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Flex	3.5L	4V	ACM(Audio control module)			V	V	V		V		V																	
Ford	Flex	3.5L	4V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Flex	3.5L	4V	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V																				
Ford	Flex	3.5L	4V	DDM(Driver's Door Module)			V	V	V	V			V																	
Ford	Flex	3.5L	4V	DSM(Driver's Seat Module)			V	V	V	V																				
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Flex	3.5L	4V	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Flex	3.5L	4V	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	Flex	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	Flex	3.5L	4V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Flex	3.5L	4V	HCM(Headlamp Control Module)			V	V	V	V	V		V																	
Ford	Flex	3.5L	4V	HCM-2(Headlamp Control Module2)			V	V	V				V																	
Ford	Flex	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Flex	3.5L	4V	IC(Instrument cluster)			V	V	V	V																				
Ford	Flex	3.5L	4V	ILCM(Interior Lighting Control Module)			V	V	V	V			V																	
Ford	Flex	3.5L	4V	LTM(Liftgate/Trunk Module)			V	V	V				V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Flex	3.5L	4V	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Flex	3.5L	4V	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Flex	3.5L	4V	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Flex	3.5L	4V	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Flex	3.5L	4V	RETM(Rear Entertainment Module)			V	V	V				V																	
Ford	Flex	3.5L	4V	SASM(Steering Angle Sensor Module)			V	V	V				V																	
Ford	Flex	3.5L	4V	Factory Keyless Entry Code																				V						
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4(4x4 Control Module)			V	V	V	V			V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio control module)			V	V	V		V		V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V																				
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)			V	V	V	V			V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V	V	V																				
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)			V	V	V	V	V		V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2(Headlamp Control Module2)			V	V	V				V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC(Instrument cluster)			V	V	V	V																				
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM(Interior Lighting Control Module)			V	V	V	V			V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)			V	V	V				V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RETM(Rear Entertainment Module)			V	V	V				V																	
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)			V	V	V				V																	
Ford	Flex	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Flex	3.5L	TiVCT	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Flex	3.5L	TiVCT	4X4(4x4 Control Module)			V	V	V	V			V																	
Ford	Flex	3.5L	TiVCT	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Flex	3.5L	TiVCT	ACM(Audio control module)			V	V	V		V		V																	
Ford	Flex	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Flex	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V																				
Ford	Flex	3.5L	TiVCT	DDM(Driver's Door Module)			V	V	V	V			V																	
Ford	Flex	3.5L	TiVCT	DSM(Driver's Seat Module)			V	V	V	V																				
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Flex	3.5L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Flex	3.5L	TiVCT	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	Flex	3.5L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	Flex	3.5L	TiVCT	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Flex	3.5L	TiVCT	HCM(Headlamp Control Module)			V	V	V	V	V		V																	
Ford	Flex	3.5L	TiVCT	HCM-2(Headlamp Control Module2)			V	V	V				V																	
Ford	Flex	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Flex	3.5L	TiVCT	IC(Instrument cluster)			V	V	V	V																				
Ford	Flex	3.5L	TiVCT	ILCM(Interior Lighting Control Module)			V	V	V	V			V																	
Ford	Flex	3.5L	TiVCT	LTM(Liftgate/Trunk Module)			V	V	V				V																	
Ford	Flex	3.5L	TiVCT	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Flex	3.5L	TiVCT	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Flex	3.5L	TiVCT	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Flex	3.5L	TiVCT	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Flex	3.5L	TiVCT	RETM(Rear Entertainment Module)			V	V	V				V																	
Ford	Flex	3.5L	TiVCT	SASM(Steering Angle Sensor Module)			V	V	V				V																	
Ford	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)				V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)				V	V	V	V					V	V	V	V	V											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)				V	V	V																					
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)				V	V	V														V							
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)				V	V	V	V											V									
Ford	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)				V		V	V																				
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)				V	V	V	V																				
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)				V		V	V																				
Ford	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)				V	V	V	V																				
Ford	FreestarMonterey	3.9L	GEM(Generic Electronic Module)				V	V	V	V														V						
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)				V	V	V	V																				
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)				V	V	V	V			V																	
Ford	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)				V		V																					
Ford	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)				V	V	V																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)				V		V	V																				
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)				V		V																					
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)				V	V	V																					
Ford	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)				V		V	V																				
Ford	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)				V		V	V																				
Ford	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)				V	V	V	V																				
Ford	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)				V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)				V	V	V	V					V	V	V	V	V											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)				V	V	V																					
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)				V	V	V														V							
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)				V	V	V	V											V									
Ford	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)				V		V	V																				
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)				V	V	V	V																				
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)				V		V	V																				
Ford	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)				V	V	V	V																				
Ford	FreestarMonterey	4.2L	GEM(Generic Electronic Module)				V	V	V	V														V						
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)				V	V	V	V																				
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)				V	V	V	V			V																	
Ford	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)				V		V																					
Ford	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)				V	V	V																					
Ford	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)				V		V	V																				
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)				V		V																					
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)				V	V	V																					
Ford	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)				V		V	V																				
Ford	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)				V		V	V																				
Ford	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)				V	V	V	V																				
Ford	Freestyle	3.0L	4V	SYSTEM SEARCH																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Freestyle	3.0L	4V	4X4(4x4 Control Module)			V	V	V				V																	
Ford	Freestyle	3.0L	4V	ABS(Anti-Lock Brake System)			V	V	V	V											V	V								
Ford	Freestyle	3.0L	4V	ACM(Audio Control Module)			V	V	V				V																	
Ford	Freestyle	3.0L	4V	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	Freestyle	3.0L	4V	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Ford	Freestyle	3.0L	4V	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Freestyle	3.0L	4V	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Freestyle	3.0L	4V	PAM(Parking Aid Module)			V	V	V	V																				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Freestyle	3.0L	4V	RCM(Restraint Control Module)			V	V	V	V			V																	
Ford	Freestyle	3.0L	4V	TCM(Transmission Control Module)			V	V	V				V	V		V	V	V	V											
Ford	Five Hundred	3.0L	4V	SYSTEM SEARCH																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V		V				V															
Ford	Five Hundred	3.0L	4V	4X4(4x4 Control Module)			V	V	V				V																	
Ford	Five Hundred	3.0L	4V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	Five Hundred	3.0L	4V	ACM(Audio Control Module)			V	V	V				V																	
Ford	Five Hundred	3.0L	4V	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	Five Hundred	3.0L	4V	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Ford	Five Hundred	3.0L	4V	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Five Hundred	3.0L	4V	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Five Hundred	3.0L	4V	PAM(Parking Aid Module)			V	V	V	V																				
Ford	Five Hundred	3.0L	4V	RCM(Restraint Control Module)			V	V	V	V			V																	
Ford	Five Hundred	3.0L	4V	TCM(Transmission Control Module)			V	V	V				V			V	V	V	V											
Ford	Ford GT	5.4L	4V	SYSTEM SEARCH																										
Ford	Ford GT	5.4L	4V	PCM(Powertrain Control Module)			V	V	V	V					V	V	V	V	V											
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)			V	V	V																					
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)			V	V	V	V														V						
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)			V	V	V	V			V											V						
Ford	Ford GT	5.4L	4V	IC(Instrument Cluster)			V	V	V	V																				
Ford	Ford GT	5.4L	4V	PATS(Passive Anti Theft System)			V	V	V	V																				
Ford	Ford GT	5.4L	4V	RCM(Restraint Control Module)			V	V	V	V													V							
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V																
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission control module)			V	V	V																					
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)			V	V	V	V			V																	
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)			V	V	V				V																	
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)			V	V	V		V	V	V	V																
Ford	Fusion	1.6L	DURATEC	TCM(Transmission control module)			V	V	V																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Fusion	1.6L	DURATEC	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Fusion	1.6L	DURATEC	IC(Instrument cluster)			V	V	V	V			V																	
Ford	Fusion	1.6L	DURATEC	ACM(Audio control module)			V	V	V				V																	
Ford	Fusion	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Ford	Fusion	1.6L	DURATEC	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Fusion	1.6L	DURATEC	SRM(Speech Recognition Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)			V	V	V		V		V											V						
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)			V	V	V		V																			
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)			V	V	V		V		V																	
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)			V	V	V		V		V											V						
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)			V	V	V		V																			
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SYSTEM SEARCH																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V															
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACM(Audio Control Module)			V	V	V	V	V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BCM(Body Control Module)			V	V	V	V	V		V											V						
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BECM(Battery Energy Control Module)			V	V	V	V	V																			
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	C-CM(Cruise Control Module)			V	V	V		V																			
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)			V	V	V		V																			
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)			V	V	V		V																			
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DDM(Driver's Door Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSM(Driver's Seat Module)			V	V	V				V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)			V	V	V	V	V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GFM(Generic Function Module)			V	V	V	V	V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GWM(Gateway Module A)			V	V	V		V																			
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)			V	V	V	V	V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HUD(Head Up Display)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPM-A(Image Processing Module A)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RACM(Rear Audio Control Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RTM(Radio Transceiver Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCCM(Steering Column Control Module)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCM-E(Seat Control Module E)			V	V	V	V																				
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V		V																			
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V		V																			
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM(Secondary OBD Control Module A)			V	V	V		V		V																	
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	TCU(Telematic Control Unit Module)			V	V	V		V		V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Fusion	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)			V	V	V	V			V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V				V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	Fusion	2.3L	DURATEC-HE/I4	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)			V	V	V	V	V		V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	PAM(Parking Aid Module)			V	V	V	V			V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V				V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)			V	V	V	V			V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)			V	V	V	V			V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)			V	V	V																					
Ford	Fusion	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Ford	Fusion	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Fusion	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)			V	V	V	V			V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Fusion	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V				V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	Fusion	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)			V	V	V	V			V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)			V	V	V																					
Ford	Fusion	2.5L	IVCT	SYSTEM SEARCH																										
Ford	Fusion	2.5L	IVCT	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V															
Ford	Fusion	2.5L	IVCT	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Fusion	2.5L	IVCT	ACM(Audio Control Module)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	IVCT	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	BCM(Body Control Module)			V	V	V	V	V		V											V						
Ford	Fusion	2.5L	IVCT	C-CM(Cruise Control Module)			V	V	V		V																			
Ford	Fusion	2.5L	IVCT	DACM-C(Digital Audio Control Module C)			V	V	V		V																			
Ford	Fusion	2.5L	IVCT	DDM(Driver's Door Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	Fusion	2.5L	IVCT	DSP(Digital Signal Processing Module)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	IVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	IVCT	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	IVCT	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	GWM(Gateway Module A)			V	V	V		V																			
Ford	Fusion	2.5L	IVCT	HUD(Head Up Display)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Fusion	2.5L	IVCT	IPM-A(Image Processing Module A)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	RACM(Rear Audio Control Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	RTM(Radio Transceiver Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	SCCM(Steering Column Control Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	IVCT	SCM-E(Seat Control Module E)			V	V	V																					
Ford	Fusion	2.5L	IVCT	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	IVCT	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)			V	V	V		V		V	V		V	V	V	V											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)			V	V	V	V			V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)			V	V	V		V										V									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)			V	V	V																					
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)			V	V	V																					
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)			V	V	V	V			V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)			V	V	V																					
Ford	Fusion	3.0L	4V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Fusion	3.0L	4V	4X4(4x4 Control Module)			V	V	V	V			V																	
Ford	Fusion	3.0L	4V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)			V	V	V				V																	
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Fusion	3.0L	4V	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	Fusion	3.0L	4V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)			V	V	V	V			V																	
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Fusion	3.0L	4V	PAM(Parking Aid Module)			V	V	V	V			V																	
Ford	Fusion	3.0L	4V	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)			V	V	V				V																	
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Fusion	3.0L	4V	TCM(Transmission Control Module)			V	V	V	V			V																	
Ford	Fusion	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Ford	Fusion	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Ford	Fusion	3.0L	4V	TBM(Tracking And Blocking Module)			V	V	V																					
Ford	Fusion	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Ford	Fusion	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Fusion	3.5L	4V	SYSTEM SEARCH																										
Ford	Fusion	3.5L	4V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Fusion	3.5L	4V	TCM(Transmission Control Module)			V	V	V	V			V																	
Ford	Fusion	3.5L	4V	4X4(4x4 Control Module)			V	V	V	V			V																	
Ford	Fusion	3.5L	4V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Ford	Fusion	3.5L	4V	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Fusion	3.5L	4V	APIM(Accessory Protocol Interface Module)			V	V	V				V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Fusion	3.5L	4V	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	Fusion	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Ford	Fusion	3.5L	4V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Fusion	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Fusion	3.5L	4V	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Fusion	3.5L	4V	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Fusion	3.5L	4V	PAM(Parking Aid Module)			V	V	V	V			V																	
Ford	Fusion	3.5L	4V	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Fusion	3.5L	4V	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Fusion	3.5L	4V	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Ford	Fusion	3.5L	4V	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Ford	Fusion	3.5L	4V	TBM(Tracking And Blocking Module)			V	V	V																					
Ford	KA	2000 MY	SYSTEM SEARCH																											
Ford	KA	2000 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	KA	2000 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Ford	KA	2000 MY	RCM(Restraint Control Module)				V	V	V	V													V							
Ford	KA	1999 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	KA	1999 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V		V																	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V	V	V		V																	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V	V	V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)			V	V	V	V	V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V	V		V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V	V	V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V		V																			
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V																			
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)			V	V	V		V																			
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)			V	V	V	V	V																			
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)			V	V	V		V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)			V	V	V	V	V																			
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)			V	V	V		V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)			V	V	V	V	V		V																	
Ford	Kuga	2.0L DIESEL	SYSTEM SEARCH																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)				V	V	V		V																			
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)				V	V	V	V	V																			
Ford	Kuga	2.0L DIESEL	TCM(Transmission Control Module)				V	V	V		V																			
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)				V	V	V	V											V									
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)				V	V	V		V																			
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)				V	V	V				V																	
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)				V	V	V		V		V																	
Ford	Kuga	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)				V	V	V		V																			
Ford	Kuga	2.0L DIESEL	APIM(Accessory Protocol Interface Module)				V	V	V		V																			
Ford	Kuga	2.0L DIESEL	AWD(All Wheel Drive Module)				V	V	V				V																	
Ford	Kuga	2.0L DIESEL	BCMii(Body Control Module)				V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Kuga	2.0L DIESEL	CCMii(Cruise Control Module)				V	V	V		V		V																	
Ford	Kuga	2.0L DIESEL	CMR(Camera Module Rear)				V	V	V																					
Ford	Kuga	2.0L DIESEL	D_DCU(Driver Door Control Unit)				V	V	V	V			V																	
Ford	Kuga	2.0L DIESEL	DDM(Driver's Door Module)				V	V	V		V		V																	
Ford	Kuga	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)				V	V	V				V																	
Ford	Kuga	2.0L DIESEL	EPS(Electronic Power Steering)				V	V	V				V																	
Ford	Kuga	2.0L DIESEL	FDSM(Front Distance Sensing Module)				V	V	V		V																			
Ford	Kuga	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)				V	V	V	V	V		V																	
Ford	Kuga	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)				V	V	V	V																				
Ford	Kuga	2.0L DIESEL	GEM(Generic Electronic Module)				V	V	V	V			V																	
Ford	Kuga	2.0L DIESEL	GPSM(Global Positioning System Module)				V	V	V		V		V																	
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)				V	V	V				V																	
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)				V	V	V		V		V																	
Ford	Kuga	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)				V	V	V		V		V																	
Ford	Kuga	2.0L DIESEL	IPM-A(Image Processing Module A)				V	V			V		V																	
Ford	Kuga	2.0L DIESEL	IPM-B(Image Processing Module B)				V	V																						
Ford	Kuga	2.0L DIESEL	IPC(Instrument Panel Control Module)				V	V	V	V	V		V																	
Ford	Kuga	2.0L DIESEL	IC(Instrument Cluster)				V	V	V	V			V																	
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)				V	V	V				V																	
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)				V	V	V		V		V																	
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)				V	V	V	V			V																	
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)				V	V	V		V		V																	
Ford	Kuga	2.0L DIESEL	PSCM(Power Steering Control Module)				V	V	V		V		V																	
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)				V	V	V																					
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)				V	V	V		V																			
Ford	Kuga	2.0L DIESEL	RFA(Remote Function Actuator)				V	V	V		V		V																	
Ford	Kuga	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)				V	V	V		V																			
Ford	Kuga	2.0L DIESEL	RETM(Rear Entertainment Module)				V	V	V																					
Ford	Kuga	2.0L DIESEL	SASM(Steering Angle Sensor Module)				V	V	V		V		V																	
Ford	Kuga	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)				V	V	V	V	V		V																	
Ford	Kuga	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)				V	V	V	V	V		V																	
Ford	Kuga	2.0L DIESEL	SRM(Speech Recognition Module)				V	V	V				V																	
Ford	Kuga	2.0L DIESEL	TRM(Trailer Module)				V	V	V	V	V																			
Ford	Kuga	2.5L	I5	SYSTEM SEARCH																										
Ford	Kuga	2.5L	I5	PCM(PowerTrain Control Module)			V	V	V		V	V	V	V																
Ford	Kuga	2.5L	I5	ABS(Anti-Lock Brake System)			V	V	V																					
Ford	Kuga	2.5L	I5	ACM(Audio Control Module)			V	V	V				V																	
Ford	Kuga	2.5L	I5	AWD(All Wheel Drive Module)			V	V	V				V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Kuga	2.5L	I5	CMR(Camera Module Rear)			V	V	V																					
Ford	Kuga	2.5L	I5	D_DCU(Driver Door Control Unit)			V	V	V	V			V																	
Ford	Kuga	2.5L	I5	EATC(Electronic Automatic Temperature Control)			V	V	V				V																	
Ford	Kuga	2.5L	I5	EPS(Electronic Power Steering)			V	V	V				V																	
Ford	Kuga	2.5L	I5	FFH(Fuel Fired Coolant Heating Module)			V	V	V	V																				
Ford	Kuga	2.5L	I5	GEM(Generic Electronic Module)			V	V	V	V			V																	
Ford	Kuga	2.5L	I5	HCM(Headlamp Control Module)			V	V	V				V																	
Ford	Kuga	2.5L	I5	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Kuga	2.5L	I5	PAM(Parking Aid Module)			V	V	V				V																	
Ford	Kuga	2.5L	I5	PDM(Passenger's Door Module)			V	V	V	V			V																	
Ford	Kuga	2.5L	I5	RCM(Restraint Control Module)			V	V	V																					
Ford	Kuga	2.5L	I5	RETM(Rear Entertainment Module)			V	V	V																					
Ford	Kuga	2.5L	I5	RKE(Remote Keyless Entry)			V	V	V				V																	
Ford	Kuga	2.5L	I5	SRM(Speech Recognition Module)			V	V	V				V																	
Ford	Kuga	2.5L	I5	TCM(Transmission Control Module)			V	V	V																					
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V		V				V															
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V		V										V									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)			V	V	V	V	V		V																	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)			V	V			V		V																	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Mondeo	2010 MY	2.5L I5	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.5L I5	PCM(PowerTrain Control Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	AHCM(Auxiliary Heater Control Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	BCMii(Body Control Module)			V	V	V	V	V																			
Ford	Mondeo	2010 MY	2.5L I5	CCMii(Cruise Control Module)			V	V	V	V	V		V																	
Ford	Mondeo	2010 MY	2.5L I5	CMR(Camera Module Rear)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	DDM(Driver's Door Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	DSM(Driver's Seat Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	HCM(Headlamp Control Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.5L I5	IPC(Instrument Panel Control Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.5L I5	PBM(Parking Brake Control Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.5L I5	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.5L I5	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	RFA(Remote Function Actuator)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	SASM(Steering Angle Sensor Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	SRM(Speech Recognition Module)			V	V	V		V		V																	
Ford	Mondeo	2010 MY	2.5L I5	TCM(Transmission Control Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	TRM(Trailer Module)			V	V	V		V																			
Ford	Mondeo	2010 MY	2.5L I5	VDM(Vehicle Dynamic Module)			V	V	V		V		V																	
Ford	Mondeo	2009 MY	2.0L DIESEL	SYSTEM SEARCH																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)			V	V	V		V																			
Ford	Mondeo	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)			V	V	V		V																			
Ford	Mondeo	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Mondeo	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)			V	V			V																			
Ford	Mondeo	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Mondeo	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)			V	V	V		V		V																	
Ford	Mondeo	2009 MY	2.0L DIESEL	BCMii(Body Control Module)			V	V	V		V																			
Ford	Mondeo	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)			V	V	V		V		V																	
Ford	Mondeo	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Mondeo	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)			V	V	V		V		V																	
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V	V		V	V	V															
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	AHCM(Auxiliary Heater Control Module)			V	V	V		V																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	BCMii(Body Control Module)			V	V	V	V	V																			
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CCMii(Cruise Control Module)			V	V	V	V	V		V																	
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CMR(Camera Module Rear)			V	V	V		V																			
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DDM(Driver's Door Module)			V	V	V		V																			
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DSM(Driver's Seat Module)			V	V	V		V																			
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HCM(HeadLamp Control Module)			V	V	V		V																			
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	IPC(Instrument Panel Control Module)			V	V	V		V																			
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PBM(Parking Brake Control Module)			V	V	V		V																			
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RFA(Remote Function Actuator)			V	V	V		V		V																	
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SASM(Steering Angle Sensor Module)			V	V	V		V																			
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SRM(Speech Recognition Module)			V	V	V		V		V																	
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TCM(Transmission Control Module)			V	V	V		V																			
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TRM(Trailer Module)			V	V	V		V																			
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	VDM(Vehicle Dynamic Module)			V	V	V		V																			
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	ABS(Anti-Lock Brake System)			V	V	V	V											V									
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	RCM(Restraint Control Module)			V	V	V																					
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	HEC(Hybrid Electrical Cluster)			V	V	V	V																				
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ABS(Anti-Lock Brake System)			V	V	V	V											V									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ACM(Audio Control Module)			V	V	V				V																	
Ford	Mondeo	2003 MY	3.0L Duratec-ST	CDP(Compact Disc Player)			V	V	V				V																	
Ford	Mondeo	2003 MY	3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)			V	V	V				V																	
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GDM(Generic Display Module)			V	V	V																					
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Mondeo	2003 MY	3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)			V	V	V	V																				
Ford	Mondeo	2003 MY	3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)			V	V	V																					
Ford	Mondeo	2003 MY	3.0L Duratec-ST	NAV(Navigation System)			V	V	V																					
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RCM(Restraint Control Module)			V	V	V																					
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RETM(Rear Entertainment Module)			V	V	V																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)			V	V	V																					
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SRM(Speech Recognition Module)			V	V	V				V																	
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	SYSTEM SEARCH																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	ABS(Anti-Lock Brake System)			V	V	V	V																				
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	EATC(Electronic Automatic Temperature Control)			V	V	V	V																				
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	HCM(Headlamp Control Module)			V	V	V																					
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	RCM(Restraint Control Module)			V	V	V	V																				
Ford	Mondeo	2000 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	1.8L	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	2000 MY	1.8L	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Mondeo	2000 MY	1.8L	CSM(Central Security Module)			V	V	V														V							
Ford	Mondeo	2000 MY	1.8L	PATS(Passive Anti Theft System)			V	V	V	V													V							
Ford	Mondeo	2000 MY	1.8L	RIM(Remote Immobilizer Module)			V	V																						
Ford	Mondeo	2000 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.0L	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	2000 MY	2.0L	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Mondeo	2000 MY	2.0L	CSM(Central Security Module)			V	V	V														V							
Ford	Mondeo	2000 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.5L	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	2000 MY	2.5L	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Mondeo	2000 MY	2.5L	CSM(Central Security Module)			V	V	V														V							
Ford	Mondeo	1999 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	1.8L	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	1999 MY	1.8L	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Mondeo	1999 MY	1.8L	CSM(Central Security Module)			V	V	V														V							
Ford	Mondeo	1999 MY	1.8L	PATS(Passive Anti Theft System)			V	V	V	V													V							
Ford	Mondeo	1999 MY	1.8L	RIM(Remote Immobilizer Module)			V	V																						
Ford	Mondeo	1999 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.0L	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	1999 MY	2.0L	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Mondeo	1999 MY	2.0L	CSM(Central Security Module)			V	V	V														V							
Ford	Mondeo	1999 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.5L	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	1999 MY	2.5L	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Mondeo	1999 MY	2.5L	CSM(Central Security Module)			V	V	V														V							
Ford	Mondeo	1998 MY	1.8L	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Mondeo	1998 MY	1.8L	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	1998 MY	1.8L	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Mondeo	1998 MY	1.8L	CSM(Central Security Module)			V	V	V														V							
Ford	Mondeo	1998 MY	1.8L	PATS(Passive Anti Theft System)			V	V	V	V													V							
Ford	Mondeo	1998 MY	1.8L	RIM(Remote Immobilizer Module)			V	V																						
Ford	Mondeo	1998 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.0L	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	1998 MY	2.0L	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Mondeo	1998 MY	2.0L	CSM(Central Security Module)			V	V	V														V							
Ford	Mondeo	1998 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.5L	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	1998 MY	2.5L	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Mondeo	1998 MY	2.5L	CSM(Central Security Module)			V	V	V														V							
Ford	Mondeo	1997 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1997 MY	1.8L	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	1997 MY	1.8L	ABS(Anti-Lock Brake System)			V	V	V																					
Ford	Mondeo	1997 MY	1.8L	PATS(Passive Anti Theft System)			V	V	V	V																				
Ford	Mondeo	1997 MY	1.8L	RIM(Remote Immobilizer Module)			V	V																						
Ford	Mondeo	1997 MY	2.0L	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	1997 MY	2.0L	ABS(Anti-Lock Brake System)			V	V	V																					
Ford	Mondeo	1997 MY	2.5L	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Mondeo	1997 MY	2.5L	ABS(Anti-Lock Brake System)			V	V	V																					
Ford	Mustang	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)			V	V	V				V																	
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Ford	Mustang	3.7L	TiVCT	BCM-B(Body Control Module B)			V	V	V	V			V																	
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Mustang	3.7L	TiVCT	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	Mustang	3.7L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Ford	Mustang	3.7L	TiVCT	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Mustang	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Mustang	3.7L	TiVCT	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Mustang	3.7L	TiVCT	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	Mustang	3.7L	TiVCT	PAM(Parking Aid Module)			V	V	V		V																			
Ford	Mustang	3.7L	TiVCT	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)			V	V	V																					
Ford	Mustang	3.8L	SYSTEM SEARCH																											
Ford	Mustang	3.8L	PCM(Powertrain Control Module)				V	V	V	V					V	V	V	V	V											
Ford	Mustang	3.8L	ABS(Anti-Lock Brake System)				V	V	V	V																				
Ford	Mustang	3.8L	GEM(Generic Electronic Module)				V		V	V																V				
Ford	Mustang	3.8L	HEC(Hybrid Electrical Cluster)				V	V	V	V																				
Ford	Mustang	3.8L	RCM(Restraint Control Module)				V	V	V																					
Ford	Mustang	3.9L	SYSTEM SEARCH																											
Ford	Mustang	3.9L	PCM(Powertrain Control Module)				V	V	V	V					V	V	V	V	V											
Ford	Mustang	3.9L	ABS(Anti-Lock Brake System)				V	V	V	V																				
Ford	Mustang	3.9L	GEM(Generic Electronic Module)				V		V	V																V				
Ford	Mustang	3.9L	HEC(Hybrid Electrical Cluster)				V	V	V	V																				
Ford	Mustang	3.9L	RCM(Restraint Control Module)				V	V	V																					
Ford	Mustang	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)			V	V	V				V																	
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Ford	Mustang	4.0L	V6 (SOHC)	BCM-B(Body Control Module B)			V	V	V	V			V																	
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Mustang	4.0L	V6 (SOHC)	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	Mustang	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Ford	Mustang	4.0L	V6 (SOHC)	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Mustang	4.0L	V6 (SOHC)	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Mustang	4.0L	V6 (SOHC)	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Mustang	4.0L	V6 (SOHC)	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Mustang	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)			V	V	V				V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Mustang	4.0L	V6 (SOHC)	PAM(Parking Aid Module)			V	V	V		V																			
Ford	Mustang	4.0L	V6 (SOHC)	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)			V	V	V																					
Ford	Mustang	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Ford	Mustang	4.0L	V6 (SOHC)	PATS(Passive Anti Theft System)-BETA																										
Ford	Mustang	4.6L	3V	SYSTEM SEARCH																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)			V	V	V				V																	
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Ford	Mustang	4.6L	3V	BCM-B(Body Control Module B)			V	V	V	V			V																	
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Mustang	4.6L	3V	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V																	
Ford	Mustang	4.6L	3V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Mustang	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)			V	V	V	V			V																	
Ford	Mustang	4.6L	3V	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)			V	V	V																					
Ford	Mustang	4.6L	3V	PATS(Passive Anti Theft System)-BETA																										
Ford	Mustang	5.0L	~ 2014	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)		V	V	V	V	V		V								V									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)		V	V	V	V			V								V									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)		V	V	V				V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)		V	V	V				V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	BCM-B(Body Control Module B)		V	V	V	V			V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)		V	V	V	V	V		V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	FDIM(Front Display Interface Module)		V	V	V	V			V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Ford	Mustang	5.0L	~ 2014	TiVCT	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)		V	V	V																					
Ford	Mustang	5.0L	2015 ~	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Mustang	5.0L	2015 ~	TiVCT	ABS(Anti-Lock Brake System)		V	V	V	V	V		V								V									
Ford	Mustang	5.0L	2015 ~	TiVCT	ACM(Audio Control Module)		V	V	V	V	V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM(Body Control Module)		V	V	V	V	V		V											V						
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM-B(Body Control Module B)		V	V	V	V	V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	C-CM(Cruise Control Module)		V	V	V		V																			
Ford	Mustang	5.0L	2015 ~	TiVCT	DACM-C(Digital Audio Control Module C)		V	V	V		V																			
Ford	Mustang	5.0L	2015 ~	TiVCT	DDM(Driver's Door Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	FCDIM(Front Control/Display Interface Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	FCIM(Front Controls Interface Module)		V	V	V	V	V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	GWM(Gateway Module A)		V	V	V		V																			
Ford	Mustang	5.0L	2015 ~	TiVCT	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	ICM(Information Center Module)		V	V	V	V	V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-A(Movable Roof Control Module A)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-B(Movable Roof Control Module B)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	PAM(Parking Aid Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	PDM(Passenger's Door Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	PSCM(Power Steering Control Module)		V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Mustang	5.0L	2015 ~	TiVCT	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	RTM(Radio Transceiver Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	SCCM(Steering Column Control Module)		V	V	V		V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	SCM-E(Seat Control Module E)		V	V	V	V																				
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Mustang	5.4L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)			V	V	V				V																	
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Ford	Mustang	5.4L	4V	BCM-B(Body Control Module B)			V	V	V	V			V																	
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Mustang	5.4L	4V	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	Mustang	5.4L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Ford	Mustang	5.4L	4V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Mustang	5.4L	4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Mustang	5.4L	4V	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Mustang	5.4L	4V	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	Mustang	5.4L	4V	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)			V	V	V																					
Ford	Mustang	5.8L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)			V	V	V				V																	
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Ford	Mustang	5.8L	4V	BCM-B(Body Control Module B)			V	V	V	V			V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)			V	V	V				V																	
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Mustang	5.8L	4V	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Ford	Mustang	5.8L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Ford	Mustang	5.8L	4V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Mustang	5.8L	4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Mustang	5.8L	4V	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Mustang	5.8L	4V	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	Mustang	5.8L	4V	PAM(Parking Aid Module)			V	V	V		V																			
Ford	Mustang	5.8L	4V	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)			V	V	V																					
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V	V	V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V	V	V		V											V						
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM-B(Body Control Module B)			V	V	V	V	V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)			V	V	V		V																			
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)			V	V	V		V																			
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V	V	V			V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)			V	V	V		V																			
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ICM(Information Center Module)			V	V	V	V	V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-A(Movable Roof Control Module A)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-B(Movable Roof Control Module B)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)			V	V	V		V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)			V	V	V	V																				
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V	V	V		V		V															
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V										V									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V	V	V		V																	
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)			V	V	V	V	V																			
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)			V	V	V																					
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V																			
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V																				
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V																				
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)			V	V	V	V			V																	
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)			V	V	V	V	V		V																	
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)			V	V	V		V																			
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)			V	V	V																					
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)			V	V	V		V		V	V	V															
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)			V		V	V																				
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)			V		V		V																			
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)			V	V	V		V																			
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Diesel(WL-CD)	SYSTEM SEARCH																											
Ford	Ranger	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Ranger	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)				V	V	V	V																				
Ford	Ranger	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)				V	V	V	V													V							
Ford	Ranger	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)				V	V	V														V							
Ford	Ranger	2.5 Diesel(WL-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.0 Diesel(WE-CD)	SYSTEM SEARCH																											
Ford	Ranger	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)				V	V	V	V	V																			
Ford	Ranger	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)				V	V	V	V																				
Ford	Ranger	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)				V	V	V	V													V							

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Ranger	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)				V	V	V														V							
Ford	Ranger	3.0 Diesel(WE-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V	V	V		V	V	V															
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V										V									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V	V	V		V																	
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)			V	V	V	V	V																			
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)			V	V	V																					
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V																				
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V																				
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)			V	V	V	V			V																	
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)			V	V	V	V	V		V																	
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)			V	V	V		V																			
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)			V	V	V																					
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)			V	V	V		V		V	V																
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)			V		V		V																			
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)			V	V	V		V																			
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)			V	V	V	V																				
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V											V		V							
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	GEM(Generic Electronic Module)			V	V	V				V																	
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	4X4(4x4 Control Module)			V	V	V																					
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V	V	V																			
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Gasoline	SYSTEM SEARCH																											
Ford	Ranger	2.5 Gasoline	PCM(PowerTrain Control Module)				V	V	V	V	V	V	V	V																
Ford	Ranger	2.5 Gasoline	ABS(Anti-Lock Brake System)				V	V	V	V	V										V									
Ford	Ranger	2.5 Gasoline	ACM(Audio Control Module)				V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Ranger	2.5 Gasoline	BCMii(Body Control Module)				V	V	V	V	V																			
Ford	Ranger	2.5 Gasoline	DDM(Driver's Door Module)				V	V	V																					
Ford	Ranger	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)				V	V	V	V	V																			
Ford	Ranger	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)				V	V	V	V																				
Ford	Ranger	2.5 Gasoline	IPC(Instrument Panel Control Module)				V	V	V	V	V		V																	
Ford	Ranger	2.5 Gasoline	PAM(Parking Aid Module)				V	V	V		V		V																	
Ford	Ranger	2.5 Gasoline	PDM(Passenger's Door Module)				V	V	V	V	V		V																	
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)				V	V	V		V																			
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)				V	V	V	V	V																			
Ford	Ranger	2.5 Gasoline	SRM(Speech Recognition Module)				V	V	V		V																			
Ford	Ranger	2.5 Gasoline	TBM(Tracking And Blocking Module)				V	V	V																					
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)				V		V	V																				
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)				V		V		V																			
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)				V		V		V																			
Ford	Ranger	2.5 Gasoline	TRM(Trailer Module)				V	V	V		V																			
Ford	Ranger	2.5 Gasoline	PATS(Passive Anti Theft System)-BETA																											
Ford	Ranger	3.0L	Other	SYSTEM SEARCH																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)			V	V	V	V																				
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)			V	V	V	V											V		V							
Ford	Ranger	3.0L	Other	GEM(Generic Electronic Module)			V	V	V				V																	
Ford	Ranger	3.0L	Other	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Ranger	3.0L	Other	OCSM(Occupant Classification System Module)			V	V	V				V																	
Ford	Ranger	3.0L	Other	4X4(4x4 Control Module)			V	V	V																					
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)			V	V	V	V	V																			
Ford	Ranger	3.0L	Other	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Ford	Ranger	3.0L	FFV	SYSTEM SEARCH																										
Ford	Ranger	3.0L	FFV	PCM(Powertrain Control Module)			V	V	V	V					V															
Ford	Ranger	3.0L	FFV	ABS(Anti-Lock Brake System)			V	V	V	V											V		V							
Ford	Ranger	3.0L	FFV	GEM(Generic Electronic Module)			V		V	V																				
Ford	Ranger	3.0L	FFV	PATS(Passive Anti Theft System)			V	V	V	V																				
Ford	Ranger	3.0L	FFV	RAP(Remote Anti-Theft/Personality Module)			V	V	V	V														V	V	V	V			
Ford	Ranger	3.0L	FFV	RCM(Restraint Control Module)			V	V	V	V																				
Ford	Ranger	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)			V	V	V	V																				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Ranger	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)			V	V	V																					
Ford	Ranger	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V								V									
Ford	Ranger	4.0L	V6 (SOHC)	IC(Instrument Cluster)			V	V	V				V																	
Ford	Ranger	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)			V	V	V	V			V																	
Ford	Ranger	4.0L	V6 (SOHC)	4X4(4x4 Control Module)			V	V	V				V																	
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)			V	V	V	V	V																			
Ford	Ranger	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Ford	Taurus	3.5L	4V	2008 ~ 2009	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Taurus	3.5L	4V	2008 ~ 2009	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	4V	2008 ~ 2009	ABS(Anti-Lock Brake System)		V	V	V	V			V								V									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ACM(Audio Control Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	4V	2008 ~ 2009	APIM(Accessory Protocol Interface Module)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2008 ~ 2009	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	4V	2008 ~ 2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Ford	Taurus	3.5L	4V	2008 ~ 2009	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V			V																	
Ford	Taurus	3.5L	4V	2008 ~ 2009	IC(Instrument Cluster)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2008 ~ 2009	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2008 ~ 2009	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2008 ~ 2009	PAM(Parking Aid Module)		V	V	V	V																				
Ford	Taurus	3.5L	4V	2008 ~ 2009	RCM(Restraint Control Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	4V	2008 ~ 2009	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2008 ~ 2009	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Ford	Taurus	3.5L	4V	2008 ~ 2009	SECM(Steering Effort Control Module)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Taurus	3.5L	4V	2010 ~ 2012	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	ABS(Anti-Lock Brake System)		V	V	V	V			V								V									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	C-CM(Cruise Control Module)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	DDM(Driver's Door Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)		V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	FDIM(Front Display Interface Module)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Ford	Taurus	3.5L	4V	2010 ~ 2012	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM(Headlamp Control Module)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM-2(Headlamp Control Module2)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	ILCM(Interior Lighting Control Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	PAM(Parking Aid Module)		V	V	V		V																			
Ford	Taurus	3.5L	4V	2010 ~ 2012	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	SASM(Steering Angle Sensor Module)		V	V	V				V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Taurus	3.5L	TiVCT	2013 ~	ABS(Anti-Lock Brake System)		V	V	V	V	V		V								V									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	BCM(Body Control Module)		V	V	V	V	V		V											V						
Ford	Taurus	3.5L	TiVCT	2013 ~	C-CM(Cruise Control Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	DDM(Driver's Door Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	DSP(Digital Signal Processing Module)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	FCDIM(Front Control/Display Interface Module)		V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Taurus	3.5L	TiVCT	2013 ~	GFM(Generic Function Module)		V	V	V	V	V																			
Ford	Taurus	3.5L	TiVCT	2013 ~	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	HCM(Headlamp Control Module)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	HSWM(Heated Steering Wheel Module)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	PAM(Parking Aid Module)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	RACM(Rear Audio Control Module)		V	V	V				V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	RCM(Restraint Control Module)		V	V	V		V																			
Ford	Taurus	3.5L	TiVCT	2013 ~	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)		V	V	V		V																			
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)		V	V	V		V																			
Ford	Taurus	3.5L	TiVCT	2013 ~	SCCM(Steering Column Control Module)		V	V	V	V	V																			
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ABS(Anti-Lock Brake System)		V	V	V	V			V								V									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	4X4(4x4 Control Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ACM(Audio Control Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	C-CM(Cruise Control Module)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DDM(Driver's Door Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSM(Driver's Seat Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)		V	V	V				V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FDIM(Front Display Interface Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM(Headlamp Control Module)		V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM-2(Headlamp Control Module2)		V	V	V				V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HUD(Head Up Display)		V	V	V		V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ILCM(Interior Lighting Control Module)		V	V	V	V			V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)		V	V	V				V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PAM(Parking Aid Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RCM(Restraint Control Module)		V	V	V		V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RETM(Rear Entertainment Module)		V	V	V				V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SASM(Steering Angle Sensor Module)		V	V	V				V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Ford	Taurus	3.0L	2000 ~	SYSTEM SEARCH																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Taurus	3.0L	2000 ~	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Ford	Taurus	3.0L	2000 ~	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Ford	Taurus	3.0L	2000 ~	GEM(Generic Electronic Module)			V	V	V	V			V											V						
Ford	Taurus	3.0L	2000 ~	IC(Instrument Cluster)			V	V	V	V			V																	
Ford	Taurus	3.0L	2000 ~	RCM(Restraint Control Module)			V	V	V																					
Ford	Taurus	3.0L	~ 1999	SYSTEM SEARCH																										
Ford	Taurus	3.0L	~ 1999	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Taurus	3.0L	~ 1999	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Taurus	3.0L	~ 1999	RCM(Restraint Control Module)			V	V	V														V							
Ford	Taurus	3.0L	~ 1999	RIM(Remote Immobilizer Module)			V	V	V	V													V							
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V		V		V																	
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V	V	V		V											V						
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)			V	V	V	V	V																			
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V																				
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)			V	V	V	V																				
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V	V	V			V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V	V	V		V																	
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V																			
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)			V	V	V	V	V		V																	
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)			V	V	V		V																			
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)			V	V	V		V																			
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V																			
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V																			
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V																			
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)			V	V	V				V																	
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V																			
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)			V	V	V	V	V																			
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)			V	V	V		V		V																	
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)			V	V	V		V		V																	
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V																			
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V																			
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)			V	V	V	V	V																			
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SYSTEM SEARCH																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PCM(PowerTrain Control Module)			V	V	V		V		V	V																
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ABS(Anti-Lock Brake System)			V	V	V		V										V									
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ACM(Audio Control Module)			V	V	V				V																	
Ford	Transit	1.8L DIESEL	2007 ~ 2009	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Transit	1.8L DIESEL	2007 ~ 2009	IC(Instrument Cluster)			V	V	V				V																	
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PAM(Parking Aid Module)			V	V	V	V																				
Ford	Transit	1.8L DIESEL	2007 ~ 2009	RCM(Restraint Control Module)			V	V	V																					
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SRM(Speech Recognition Module)			V	V	V		V		V																	
Ford	Transit	2.0L	2001 ~ 2004	SYSTEM SEARCH																										
Ford	Transit	2.0L	2001 ~ 2004	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.0L	2001 ~ 2004	ASM(Auto Shift Manual)			V	V	V																					
Ford	Transit	2.0L	2001 ~ 2004	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Transit	2.0L	2001 ~ 2004	HEC(Hybrid Electrical Cluster)			V	V	V																					
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)			V	V	V																					
Ford	Transit	2.3L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)			V	V	V		V		V	V																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)			V	V	V																					
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Transit	2.3L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)			V	V	V																					
Ford	Transit	2.3L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)			V	V	V																					
Ford	Transit	2.3L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)			V	V	V		V		V																	
Ford	Transit	2.3L DIESEL	2004 ~ 2006	BCMii(Body Control Module)			V	V	V		V		V																	
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ACM(Audio Control Module)			V	V			V		V																	
Ford	Transit	2.4L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)			V	V	V	V																				
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)			V	V	V		V		V	V																
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)			V	V	V																					
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)			V	V	V	V													V							
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)			V	V	V																					
Ford	Transit	2.4L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)			V	V	V																					
Ford	Transit	2.4L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)			V	V	V		V		V																	
Ford	Transit	2.4L DIESEL	2004 ~ 2006	BCMii(Body Control Module)			V	V	V		V		V																	
Ford	Transit	2.4L DIESEL	2004 ~ 2006	CSM(Central Security Module)			V	V	V														V							
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ACM(Audio Control Module)			V	V			V		V																	
Ford	Transit	2.4L DIESEL	2006.5	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2006.5	PCM(PowerTrain Control Module)			V	V	V		V		V																	
Ford	Transit	2.4L DIESEL	2006.5	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Transit	2.4L DIESEL	2006.5	ACM(Audio Control Module)			V	V	V		V												V							
Ford	Transit	2.4L DIESEL	2006.5	BCMii(Body Control Module)			V	V	V		V		V																	
Ford	Transit	2.4L DIESEL	2006.5	FFH(Fuel Fired Coolant Heating Module)			V	V	V																					
Ford	Transit	2.4L DIESEL	2006.5	IPC(Instrument Panel Control Module)			V	V	V		V																			
Ford	Transit	2.4L DIESEL	2006.5	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Transit	2.4L DIESEL	2006.5	RCM(Restraint Control Module)			V	V	V																					
Ford	Transit	2.4L DIESEL	2006.5	TBM(Tracking And Blocking Module)			V	V	V																					
Ford	Transit	2.5L DIESEL	SYSTEM SEARCH																											
Ford	Transit	2.5L DIESEL	PCM(PowerTrain Control Module)				V	V	V	V																				
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	ASM(Auto Shift Manual)				V	V	V																					
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)			V	V	V														V							
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)			V	V	V														V							

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Transit	2.5L DIESEL	RCM(Restraint Control Module)				V	V	V	V													V							
Ford	Transit	2.5L DIESEL	HEC(Hybrid Electrical Cluster)				V	V	V																					
Ford	Transit	2.5L DIESEL	CSM(Central Security Module)				V	V	V														V							
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)				V	V	V	V																				
Ford	Transit	2.5L DIESEL	RIM(Remote Immobilizer Module)				V	V																						
Ford	Transit	2.5L DIESEL	ACM(Audio Control Module)				V	V			V		V																	
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V		V		V																	
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V		V																			
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V		V												V							
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)			V	V	V		V		V																	
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)			V	V	V																					
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)			V	V	V		V																			
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V																					
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V		V																	
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V	V	V		V																	
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Control Module)			V	V	V		V																			
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V		V		V																	
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V		V																			
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V																			
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)			V	V	V		V																			
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)			V	V	V																					
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)			V	V	V		V																			
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)			V	V	V		V																			
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)			V	V	V																					
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)			V	V	V	V	V		V																	
Ford	Transit	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Transit	3.7L	TiVCT	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Ford	Transit	3.7L	TiVCT	ABS(Anti-Lock Brake System)			V	V	V	V	V		V																	
Ford	Transit	3.7L	TiVCT	ACM(Audio Control Module)			V	V	V	V	V		V																	
Ford	Transit	3.7L	TiVCT	APIM(Accessory Protocol Control Module)			V	V	V		V																			
Ford	Transit	3.7L	TiVCT	BCM(Body Control Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Ford	Transit	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Ford	Transit	3.7L	TiVCT	FCIM(Front Controls Interface Module)			V	V	V		V																			
Ford	Transit	3.7L	TiVCT	GPSM(Global Positioning System Module)			V	V	V		V																			
Ford	Transit	3.7L	TiVCT	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Ford	Transit	3.7L	TiVCT	IPM-A(Image Processing Module A)			V	V	V		V																			
Ford	Transit	3.7L	TiVCT	IPM-B(Image Processing Module B)			V	V	V																					
Ford	Transit	3.7L	TiVCT	PAM(Park Aid Module)			V	V	V		V																			
Ford	Transit	3.7L	TiVCT	RCM(Restraint Control Module)			V	V	V		V		V																	
Ford	Transit	3.7L	TiVCT	SASM(Steering Angle Sensor Module)			V	V	V		V																			
Ford	Transit	3.7L	TiVCT	TBC(Trailer Brake Control Module)			V	V	V																					
Ford	Transit	3.7L	TiVCT	TRM(Trailer Module)			V	V	V	V	V		V																	
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V	V	V		V		V	V																
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V	V		V										V									
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)			V	V	V				V																	
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)			V	V	V	V																				
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)			V	V	V				V																	
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)			V	V	V	V																				
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V	V	V																					
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)			V	V	V		V		V																	
Ford	Thunderbird	3.9L	4V	SYSTEM SEARCH																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)			V	V	V	V					V	V	V	V	V											
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)			V	V	V																					
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)			V	V	V														V							
Ford	Thunderbird	3.9L	4V	ACM(Audio Control Module)			V	V	V																					
Ford	Thunderbird	3.9L	4V	DDM(Driver's Door Module)			V	V	V																					
Ford	Thunderbird	3.9L	4V	EATC(Electronic Automatic Temperature Control)			V	V	V	V																				
Ford	Thunderbird	3.9L	4V	GEM(Generic Electronic Module)			V	V	V	V														V						
Ford	Thunderbird	3.9L	4V	HEC(Hybrid Electrical Cluster)			V	V	V	V																				
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)			V	V	V	V													V							
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)			V	V	V																					
Ford	Thunderbird	3.9L	4V	REM(Rear Electronic Module)			V	V	V	V																				
Lincoln	Aviator	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Aviator	4.6L	4V	PCM(Powertrain Control Module)			V	V	V	V																				
Lincoln	Aviator	4.6L	4V	ABS(Anti-Lock Brake System)			V	V	V																					
Lincoln	Aviator	4.6L	4V	DCSM(Driver-Dual Climate Control Seat Module)			V		V																					
Lincoln	Aviator	4.6L	4V	DSM(Driver's Seat Module)			V		V																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	Aviator	4.6L	4V	EATC(Electronic Automatic Temperature Control)			V	V	V																					
Lincoln	Aviator	4.6L	4V	IC(Instrument Cluster)			V	V	V																					
Lincoln	Aviator	4.6L	4V	PAM(Parking Aid Module)			V		V	V																				
Lincoln	Aviator	4.6L	4V	RCM(Restraint Control Module)			V		V																					
Lincoln	Aviator	4.6L	4V	TPM(Tire Pressure Monitor)			V	V	V																					
Lincoln	Aviator	4.6L	4V	VAPS(Variable Assist Power Steering)			V	V	V																					
Lincoln	Aviator	4.6L	4V	VSM(Vehicle Security Module)			V	V	V	V																				
Lincoln	Continental	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Continental	4.6L	4V	PCM(PowerTrain Control Module)			V	V	V	V					V															
Lincoln	Continental	4.6L	4V	ABS(Anti-Lock Brake System)			V	V	V	V											V									
Lincoln	Continental	4.6L	4V	ACM(Audio Control Module)			V	V	V																					
Lincoln	Continental	4.6L	4V	CPM(Cellular Phone Module)			V	V	V	V																				
Lincoln	Continental	4.6L	4V	DDM(Driver's Door Module)			V	V	V	V														V	V	V	V	V		
Lincoln	Continental	4.6L	4V	DSM(Driver's Seat Module)			V	V	V	V																				
Lincoln	Continental	4.6L	4V	LCM(Lighting Control Module)			V	V	V	V																				
Lincoln	Continental	4.6L	4V	NGSC(Next Generation Speed Control Module)			V	V	V																					
Lincoln	Continental	4.6L	4V	RCM(Restraint Control Module)			V	V	V	V																				
Lincoln	Continental	4.6L	4V	VDM(Vehicle Dynamic Module)			V	V	V	V																				
Lincoln	Continental	4.6L	4V	VIC(Virtual Image Cluster)			V	V	V	V																				
Lincoln	Continental	4.6L	4V	EATC(Electronic Automatic Temperature Control)			V	V	V																					
Lincoln	Continental	4.6L	4V	PATS(Passive Anti Theft System)																										
Lincoln	LS	ALL	SYSTEM SEARCH																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)				V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Lincoln	LS	ALL	PCM(Powertrain Control Module)				V	V	V	V					V	V	V	V	V											
Lincoln	LS	ALL	ABS(Anti-Lock Brake System)				V	V	V	V											V									
Lincoln	LS	ALL	DCSM(Driver-Dual Climate Control Seat Module)				V		V	V																				
Lincoln	LS	ALL	DDM(Driver's Door Module)				V	V	V																					
Lincoln	LS	ALL	DSM(Driver's Seat Module)				V	V	V	V																				
Lincoln	LS	ALL	EPB(Electronic Parking Brake)				V	V	V	V																				
Lincoln	LS	ALL	PAM(Parking Aid Module)				V		V																					
Lincoln	LS	ALL	RCM(Restraint Control Module)				V		V																					
Lincoln	LS	ALL	REM(Rear Electronic Module)				V	V	V	V																				
Lincoln	LS	ALL	REM(Rear Electronic Module)				V	V	V	V																				
Lincoln	LS	ALL	SCLM(Steering Column Locking Module)				V	V	V																					
Lincoln	LS	ALL	EATC(Electronic Automatic Temperature Control)				V	V	V	V																				
Lincoln	LS	ALL	GEM(Generic Electronic Module)				V	V	V	V																				
Lincoln	LS	ALL	HEC(Hybrid Electrical Cluster)				V	V	V	V																				
Lincoln	LS	ALL	PCSM(Passenger Climate Control Seat Module)				V		V	V																				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	MKS	3.7L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2009	PCM(Powertrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Lincoln	MKS	3.7L	4V	2009	4X4(4x4 Control Module)		V	V	V	V			V																	
Lincoln	MKS	3.7L	4V	2009	ABS(Anti-Lock Brake System)		V	V	V	V			V								V									
Lincoln	MKS	3.7L	4V	2009	ACM(Audio Control Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2009	APIM(Accessory Protocol Interface Module)		V	V	V				V																	
Lincoln	MKS	3.7L	4V	2009	C-CM(Cruise Control Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Lincoln	MKS	3.7L	4V	2009	DDM(Driver's Door Module)		V	V	V	V			V																	
Lincoln	MKS	3.7L	4V	2009	DSM(Driver's Seat Module)		V	V	V	V																				
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2009	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2009	FDIM(Front Display Interface Module)		V	V	V	V			V																	
Lincoln	MKS	3.7L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Lincoln	MKS	3.7L	4V	2009	HCM(Headlamp Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.7L	4V	2009	HCM-2(Headlamp Control Module2)		V	V	V				V																	
Lincoln	MKS	3.7L	4V	2009	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Lincoln	MKS	3.7L	4V	2009	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.7L	4V	2009	OCSM(Occupant Classification System Module)		V	V	V				V																	
Lincoln	MKS	3.7L	4V	2009	PAM(Parking Aid Module)		V	V	V				V																	
Lincoln	MKS	3.7L	4V	2009	RCM(Restraint Control Module)		V	V	V	V			V																	
Lincoln	MKS	3.7L	4V	2009	RFA(Remote Function Actuator)		V	V	V		V																			
Lincoln	MKS	3.7L	4V	2010 ~	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2010 ~	PCM(PowerTrain Control Module)		V	V	V		V	V	V	V	V	V	V	V	V											
Lincoln	MKS	3.7L	4V	2010 ~	4X4(4x4 Control Module)		V	V	V	V			V																	
Lincoln	MKS	3.7L	4V	2010 ~	ABS(Anti-Lock Brake System)		V	V	V	V			V								V									
Lincoln	MKS	3.7L	4V	2010 ~	ACM(Audio Control Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	C-CM(Cruise Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Lincoln	MKS	3.7L	4V	2010 ~	DDM(Driver's Door Module)		V	V	V	V			V																	
Lincoln	MKS	3.7L	4V	2010 ~	DSM(Driver's Seat Module)		V	V	V				V																	
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	FDIM(Front Display Interface Module)		V	V	V	V			V																	
Lincoln	MKS	3.7L	4V	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V			V											V						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	MKS	3.7L	4V	2010 ~	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	HCM(Headlamp Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	HCM-2(Headlamp Control Module2)		V	V	V				V																	
Lincoln	MKS	3.7L	4V	2010 ~	HUD(Head Up Display)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	ILCM(Interior Lighting Control Module)		V	V	V	V			V																	
Lincoln	MKS	3.7L	4V	2010 ~	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	PAM(Parking Aid Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	RCM(Restraint Control Module)		V	V	V		V																			
Lincoln	MKS	3.7L	4V	2010 ~	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	SASM(Steering Angle Sensor Module)		V	V	V				V																	
Lincoln	MKS	3.7L	4V	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Lincoln	MKS	3.7L	4V	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS(Anti-Lock Brake System)		V	V	V	V			V								V									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	4X4(4x4 Control Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM(Audio Control Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	C-CM(Cruise Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM(Driver's Door Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM(Driver's Seat Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FDIM(Front Display Interface Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM(Headlamp Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM-2(Headlamp Control Module2)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HUD(Head Up Display)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ILCM(Interior Lighting Control Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM(Parking Aid Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM(Restraint Control Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM(Rear Entertainment Module)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM(Steering Angle Sensor Module)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS(Anti-Lock Brake System)		V	V	V	V			V								V									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	4X4(4x4 Control Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM(Audio Control Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	C-CM(Cruise Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM(Driver's Door Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM(Driver's Seat Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDIM(Front Display Interface Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM(Headlamp Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM-2(Headlamp Control Module2)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HUD(Head Up Display)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ILCM(Interior Lighting Control Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)		V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM(Parking Aid Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM(Power Steering Control Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM(Restraint Control Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RETM(Rear Entertainment Module)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM(Steering Angle Sensor Module)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ABS(Anti-Lock Brake System)		V	V	V	V			V								V									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	4X4(4x4 Control Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ACM(Audio Control Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	APIM(Accessory Protocol Interface Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	C-CM(Cruise Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DDM(Driver's Door Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSM(Driver's Seat Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FDIM(Front Display Interface Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GPSM(Global Positioning System Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM(Headlamp Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM-2(Headlamp Control Module2)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HUD(Head Up Display)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ILCM(Interior Lighting Control Module)		V	V	V	V			V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	IPC(Instrument Panel Control Module)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PAM(Parking Aid Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PSCM(Power Steering Control Module)		V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RCM(Restraint Control Module)		V	V	V		V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RFA(Remote Function Actuator)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RETM(Rear Entertainment Module)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SASM(Steering Angle Sensor Module)		V	V	V				V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-L(Side Obstacle Detection Control Module Left)		V	V	V	V	V		V																	
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-R(Side Obstacle Detection Control Module Right)		V	V	V	V	V		V																	
Lincoln	MKX	3.5L	4V	2007	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKX	3.5L	4V	2007	4X4(4x4 Control Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2007	ABS(Anti-Lock Brake System)		V	V	V	V											V									
Lincoln	MKX	3.5L	4V	2007	ACM(Audio Control Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2007	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2007	DSM(Driver's Seat Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2007	DSP(Digital Signal Processing Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2007	EATC(Electronic Automatic Temperature Control)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2007	GEM(Generic Electronic Module)		V	V	V																					
Lincoln	MKX	3.5L	4V	2007	HCM(Headlamp Control Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2007	IC(Instrument Cluster)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2007	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2007	OCSM(Occupant Classification System Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2007	PAM(Parking Aid Module)		V	V	V	V																				
Lincoln	MKX	3.5L	4V	2007	RCM(Restraint Control Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2007	RETM(Rear Entertainment Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2007	SASM(Steering Angle Sensor Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2007	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2008	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKX	3.5L	4V	2008	4X4(4x4 Control Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2008	ABS(Anti-Lock Brake System)		V	V	V	V											V									
Lincoln	MKX	3.5L	4V	2008	ACM(Audio Control Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2008	APIM(Accessory Protocol Interface Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2008	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2008	DSM(Driver's Seat Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2008	DSP(Digital Signal Processing Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Lincoln	MKX	3.5L	4V	2008	HCM(Headlamp Control Module)		V	V	V	V			V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	MKX	3.5L	4V	2008	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V																				
Lincoln	MKX	3.5L	4V	2008	IC(Instrument Cluster)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2008	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2008	OCSM(Occupant Classification System Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2008	PAM(Parking Aid Module)		V	V	V	V																				
Lincoln	MKX	3.5L	4V	2008	RCM(Restraint Control Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2008	RETM(Rear Entertainment Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2008	SASM(Steering Angle Sensor Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2008	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKX	3.5L	4V	2009	4X4(4x4 Control Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2009	ABS(Anti-Lock Brake System)		V	V	V	V											V									
Lincoln	MKX	3.5L	4V	2009	ACM(Audio Control Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2009	APIM(Accessory Protocol Interface Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2009	DSM(Driver's Seat Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKX	3.5L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Lincoln	MKX	3.5L	4V	2009	HCM(Headlamp Control Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2009	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V																				
Lincoln	MKX	3.5L	4V	2009	IC(Instrument Cluster)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2009	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2009	OCSM(Occupant Classification System Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2009	PAM(Parking Aid Module)		V	V	V	V																				
Lincoln	MKX	3.5L	4V	2009	RCM(Restraint Control Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2009	RETM(Rear Entertainment Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2009	SASM(Steering Angle Sensor Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2009	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2010	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)		V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	MKX	3.5L	4V	2010	4X4(4x4 Control Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2010	ABS(Anti-Lock Brake System)		V	V	V	V											V									
Lincoln	MKX	3.5L	4V	2010	ACM(Audio Control Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2010	APIM(Accessory Protocol Interface Module)		V	V	V				V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	MKX	3.5L	4V	2010	DCSM(Driver-Dual Climate Control Seat Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2010	DSM(Driver's Seat Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)		V	V	V		V		V																	
Lincoln	MKX	3.5L	4V	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)		V	V	V	V														V						
Lincoln	MKX	3.5L	4V	2010	HCM(Headlamp Control Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2010	HVAC(Heating Ventilation Air Conditioning)		V	V	V	V																				
Lincoln	MKX	3.5L	4V	2010	IC(Instrument Cluster)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2010	LTM(Liftgate/Trunk Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2010	OCSM(Occupant Classification System Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2010	PAM(Parking Aid Module)		V	V	V	V																				
Lincoln	MKX	3.5L	4V	2010	RCM(Restraint Control Module)		V	V	V	V			V																	
Lincoln	MKX	3.5L	4V	2010	RETM(Rear Entertainment Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2010	SASM(Steering Angle Sensor Module)		V	V	V				V																	
Lincoln	MKX	3.5L	4V	2010	SDARS(Satellite Digital Audio Receiver System)		V	V	V	V			V																	
Lincoln	MKZ	3.0L	2006	SYSTEM SEARCH																										
Lincoln	MKZ	3.0L	2006	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Lincoln	MKZ	3.0L	2006	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Lincoln	MKZ	3.0L	2006	ACM(Audio Control Module)			V	V	V				V																	
Lincoln	MKZ	3.0L	2006	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Lincoln	MKZ	3.0L	2006	DDM(Driver's Door Module)			V	V	V	V			V																	
Lincoln	MKZ	3.0L	2006	DSM(Driver's Seat Module)			V	V	V	V																				
Lincoln	MKZ	3.0L	2006	DSP(Digital Signal Processing Module)			V	V	V				V																	
Lincoln	MKZ	3.0L	2006	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Lincoln	MKZ	3.0L	2006	GEM(Generic Electronic Module)			V	V	V				V																	
Lincoln	MKZ	3.0L	2006	IC(Instrument Cluster)			V	V	V	V			V																	
Lincoln	MKZ	3.0L	2006	OCSM(Occupant Classification System Module)			V	V	V				V																	
Lincoln	MKZ	3.0L	2006	RCM(Restraint Control Module)			V	V	V																					
Lincoln	MKZ	3.0L	2006	TCM(Transmission Control Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2007	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2007	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Lincoln	MKZ	3.5L	2007	TCM(Transmission Control Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2007	4X4(4x4 Control Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2007	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Lincoln	MKZ	3.5L	2007	ACM(Audio Control Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2007	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2007	DDM(Driver's Door Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2007	DSM(Driver's Seat Module)			V	V	V	V			V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	MKZ	3.5L	2007	DSP(Digital Signal Processing Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2007	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2007	GEM(Generic Electronic Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2007	IC(Instrument Cluster)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2007	OCSM(Occupant Classification System Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2007	RCM(Restraint Control Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2007	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2007	PATS(Passive Anti Theft System)																										
Lincoln	MKZ	3.5L	2008	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2008	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Lincoln	MKZ	3.5L	2008	4X4(4x4 Control Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2008	ABS(Anti-Lock Brake System)			V	V	V				V								V									
Lincoln	MKZ	3.5L	2008	ACM(Audio Control Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2008	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2008	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2008	DDM(Driver's Door Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2008	DSM(Driver's Seat Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Lincoln	MKZ	3.5L	2008	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2008	IC(Instrument Cluster)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2008	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2008	PAM(Parking Aid Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2008	RCM(Restraint Control Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2008	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2008	TCM(Transmission Control Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2009	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2009	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Lincoln	MKZ	3.5L	2009	4X4(4x4 Control Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2009	ABS(Anti-Lock Brake System)			V	V	V				V								V									
Lincoln	MKZ	3.5L	2009	ACM(Audio Control Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2009	APIM(Accessory Protocol Interface Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2009	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2009	DDM(Driver's Door Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2009	DSM(Driver's Seat Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	MKZ	3.5L	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Lincoln	MKZ	3.5L	2009	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2009	IC(Instrument Cluster)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2009	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2009	PAM(Parking Aid Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2009	RCM(Restraint Control Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2009	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2009	TCM(Transmission Control Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2010	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2010	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Lincoln	MKZ	3.5L	2010	4X4(4x4 Control Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2010	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Lincoln	MKZ	3.5L	2010	ACM(Audio Control Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2010	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2010	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2010	DDM(Driver's Door Module)			V	V	V	V																				
Lincoln	MKZ	3.5L	2010	DSM(Driver's Seat Module)			V	V	V	V																				
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2010	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2010	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Lincoln	MKZ	3.5L	2010	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2010	HCM(Headlamp Control Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2010	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Lincoln	MKZ	3.5L	2010	ILCM(Interior Lighting Control Module)			V	V	V	V			V																	
Lincoln	MKZ	3.5L	2010	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Lincoln	MKZ	3.5L	2010	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2010	PAM(Parking Aid Module)			V	V	V				V																	
Lincoln	MKZ	3.5L	2010	RCM(Restraint Control Module)			V	V	V		V		V																	
Lincoln	MKZ	3.5L	2010	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Lincoln	MKZ	3.5L	2010	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Lincoln	MKZ	3.5L	2010	TCM(Transmission Control Module)			V	V	V				V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V															
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACCM(Air Conditioning Control Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V	V	V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V	V	V		V											V						
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BECM(Battery Energy Control Module)			V	V	V	V	V																			
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)			V	V	V		V																			
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)			V	V	V		V																			
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCDC(DC to DC Converter Control Module)			V	V	V		V																			
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V	V	V			V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)			V	V	V		V																			
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GSM(Gear Shift Module)			V	V	V		V																			
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V																			
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)			V	V	V	V																				
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G(Seat Control Module G)			V	V	V		V																			
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-H(Seat Control Module H)			V	V	V		V																			
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRCM(Transmission Range Control Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)			V	V	V		V																			
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOBDM-C(Secondary OBD Control Module C)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V															
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)			V	V	V	V	V		V								V									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM(Audio Control Module)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM(Body Control Module)			V	V	V	V	V		V											V						
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM(Battery Energy Control Module)			V	V	V	V	V																			
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM(Cruise Control Module)			V	V	V		V																			
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)			V	V	V		V																			
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)			V	V	V		V																			
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM(Driver's Door Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM(Driver's Seat Module)			V	V	V	V			V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM(Gateway Module A)			V	V	V		V																			
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM(Gear Shift Module)			V	V	V		V																			
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM(Headlamp Control Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD(Head Up Display)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A(Image Processing Module A)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM(Parking Aid Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM(Passenger's Door Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM(Rear Audio Control Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM(Restraint Control Module)			V	V	V		V																			
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM(Rear Gate/Trunk Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM(Radio Transceiver Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM(Steering Column Control Module)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E(Seat Control Module E)			V	V	V	V																				
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G(Seat Control Module G)			V	V	V		V																			
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H(Seat Control Module H)			V	V	V		V																			
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM(Transmission Range Control Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM(Vehicle Dynamic Module)			V	V	V		V																			
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)			V	V	V		V		V																	
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM(Generic Function Module)			V	V	V		V		V																	
Lincoln	Navigator	2007 ~	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V															
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)			V	V	V														V							
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)			V	V	V	V			V																	
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)			V	V	V		V		V																	
Lincoln	Navigator	2007 ~	5.4L	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Lincoln	Navigator	2007 ~	5.4L	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Lincoln	Navigator	2007 ~	5.4L	DSM(Driver's Seat Module)			V	V	V	V			V																	
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)			V	V	V				V																	
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V													V							
Lincoln	Navigator	2007 ~	5.4L	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Lincoln	Navigator	2007 ~	5.4L	IC(Instrument Cluster)			V	V	V	V			V																	
Lincoln	Navigator	2007 ~	5.4L	LTM(Liftgate/Trunk Module)			V	V	V				V																	
Lincoln	Navigator	2007 ~	5.4L	PAM(Parking Aid Module)			V	V	V																					
Lincoln	Navigator	2007 ~	5.4L	PRB(Power Running Board)			V	V	V	V			V																	
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)			V	V	V	V			V																	
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)			V	V	V		V		V																	
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)			V	V	V	V													V							
Lincoln	Navigator	2007 ~	5.4L	RCU(Audio Rear Control Unit)			V	V	V	V																				
Lincoln	Navigator	2007 ~	5.4L	RETM(Rear Entertainment Module)			V	V	V				V																	
Lincoln	Navigator	2007 ~	5.4L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Lincoln	Navigator	2007 ~	5.4L	TCCM(Transfer Case Control Module)			V	V	V	V	V																			
Lincoln	Navigator	2007 ~	5.4L	TCM(Transmission Control Module)			V	V	V	V			V			V	V	V	V											
Lincoln	Navigator	2007 ~	5.4L	VDM(Vehicle Dynamic Module)			V	V	V	V			V																	V
Lincoln	Navigator	2007 ~	5.4L	4X4(4x4 Control Module)			V	V	V	V			V																	
Lincoln	Navigator	2007 ~	5.4L	PATS(Passive Anti Theft System)																										
Lincoln	Navigator	~ 2007	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)			V	V	V	V																				
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)			V	V	V														V							
Lincoln	Navigator	~ 2007	5.4L	DCSM(Driver-Dual Climate Control Seat Module)			V	V	V	V			V																	
Lincoln	Navigator	~ 2007	5.4L	DSM(Driver's Seat Module)			V	V	V	V			V																	
Lincoln	Navigator	~ 2007	5.4L	GEM(Generic Electronic Module)			V	V	V	V													V							
Lincoln	Navigator	~ 2007	5.4L	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Lincoln	Navigator	~ 2007	5.4L	IC(Instrument Cluster)			V	V	V	V			V																	
Lincoln	Navigator	~ 2007	5.4L	LTM(Liftgate/Trunk Module)			V	V	V				V																	
Lincoln	Navigator	~ 2007	5.4L	PAM(Parking Aid Module)			V		V																					
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)			V	V	V	V			V																	
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)			V	V	V																					
Lincoln	Navigator	~ 2007	5.4L	VDM(Vehicle Dynamic Module)			V	V	V																					
Lincoln	Navigator	~ 2007	5.4L	RIM(Remote Immobilizer Module)			V	V	V	V													V							
Lincoln	Navigator	~ 2007	5.4L	VSM(Vehicle Security Module)			V	V	V	V			V											V						
Lincoln	Town Car	4.6L	2V	SYSTEM SEARCH																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)			V	V	V	V					V	V	V	V	V											
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V									
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)			V	V	V																					
Lincoln	Town Car	4.6L	2V	EATC(Electronic Automatic Temperature Control)			V	V	V	V																				
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)			V	V	V	V			V																	
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)			V	V	V	V																				
Lincoln	Town Car	4.6L	2V	LCM(Lighting Control Module)			V	V	V	V																				
Lincoln	Town Car	4.6L	2V	VDM(Vehicle Dynamic Module)			V	V	V	V			V																	V
Lincoln	Town Car	4.6L	2V	DDM(Driver's Door Module)			V	V	V	V														V	V	V	V	V	V	
Lincoln	Town Car	4.6L	2V	DSM(Driver's Seat Module)			V	V	V	V																				
Lincoln	Town Car	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V																				
Lincoln	Town Car	4.6L	2V	RATC(Rear Air Temperature Control)			V	V	V																					
Lincoln	Town Car	4.6L	2V	LTM(Liftgate/Trunk Module)			V	V	V																					
Lincoln	Town Car	4.6L	2V	PAM(Parking Aid Module)			V		V																					
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)			V	V	V																					
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)			V	V	V														V							
Lincoln	Town Car	4.6L	2V	HEC(Hybrid Electrical Cluster)			V	V	V	V																				
Lincoln	Town Car	4.6L	2V	NGSC(Next Generation Speed Control Module)			V	V	V																					
Lincoln	Town Car	4.6L	2V	RASM(Rear Air Suspension Module)			V	V	V	V																				
Mercury	Grand Marquis	4.6L	2V	SYSTEM SEARCH																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)			V	V	V	V																				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)			V	V	V														V							
Mercury	Grand Marquis	4.6L	2V	DDM(Driver's Door Module)			V	V	V	V														V	V	V	V	V	V	
Mercury	Grand Marquis	4.6L	2V	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Grand Marquis	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)			V	V	V																					
Mercury	Grand Marquis	4.6L	2V	LCM(Lighting Control Module)			V	V	V	V																				
Mercury	Grand Marquis	4.6L	2V	MC(Message Center)			V	V	V																					
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)			V	V	V																					
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)			V	V	V														V							
Mercury	Grand Marquis	4.6L	2V	RIM(Remote Immobilizer Module)			V	V	V	V													V							
Mercury	Grand Marquis	4.6L	2V	GEM(Generic Electronic Module)			V	V	V	V													V							
Mercury	Grand Marquis	4.6L	2V	VDM(Vehicle Dynamic Module)			V	V	V	V			V																	V
Mercury	Marauder	4.6L	4V	SYSTEM SEARCH																										
Mercury	Marauder	4.6L	4V	PCM(Powertrain Control Module)			V	V	V	V					V	V	V	V	V											
Mercury	Marauder	4.6L	4V	ABS(Anti-Lock Brake System)			V	V	V	V											V									
Mercury	Marauder	4.6L	4V	EATC(Electronic Automatic Temperature Control)			V	V	V																					
Mercury	Marauder	4.6L	4V	RASM(Rear Air Suspension Module)			V	V	V	V																				
Mercury	Marauder	4.6L	4V	VAPS(Variable Assist Power Steering)			V	V	V																					
Mercury	Marauder	4.6L	4V	DDM(Driver's Door Module)			V	V	V	V														V						
Mercury	Marauder	4.6L	4V	LCM(Lighting Control Module)			V	V	V	V																				
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)			V	V	V																					
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)			V	V	V	V													V							
Mercury	Milan	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Mercury	Milan	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V				V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Mercury	Milan	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	Milan	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Mercury	Milan	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)			V	V	V																					
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)			V	V	V		V		V	V		V	V	V	V											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)			V	V	V		V										V									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)			V	V	V																					
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)			V	V	V																					
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V														V						
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)			V	V	V		V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)			V	V	V																					
Mercury	Milan	3.0L	4V	SYSTEM SEARCH																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Mercury	Milan	3.0L	4V	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Milan	3.0L	4V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)			V	V	V				V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	Milan	3.0L	4V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)			V	V	V		V		V																	
Mercury	Milan	3.0L	4V	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Mercury	Milan	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Mercury	Milan	3.0L	4V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V	V		V																	
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)			V	V	V	V	V		V																	
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	Milan	3.0L	4V	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Milan	3.0L	4V	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)			V	V	V		V		V																	
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)			V	V	V				V																	
Mercury	Milan	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Mercury	Milan	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Mercury	Milan	3.0L	4V	TCM(Transmission Control Module)			V	V	V	V			V																	
Mercury	Milan	3.0L	4V	TBM(Tracking And Blocking Module)			V	V	V																					
Mercury	Milan	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Mercury	Milan	3.0L	4V	PATS(Passive Anti Theft System)																										
Mercury	Montego	3.0L	4V	SYSTEM SEARCH																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V	V																				
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V		V				V															
Mercury	Montego	3.0L	4V	4X4(4x4 Control Module)			V	V	V				V																	
Mercury	Montego	3.0L	4V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Mercury	Montego	3.0L	4V	ACM(Audio Control Module)			V	V	V				V																	
Mercury	Montego	3.0L	4V	DSM(Driver's Seat Module)			V	V	V	V			V																	
Mercury	Montego	3.0L	4V	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Mercury	Montego	3.0L	4V	GEM(Generic Electronic Module)			V	V	V	V			V																	
Mercury	Montego	3.0L	4V	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Montego	3.0L	4V	PAM(Parking Aid Module)			V	V	V	V																				
Mercury	Montego	3.0L	4V	RCM(Restraint Control Module)			V	V	V	V			V																	
Mercury	Montego	3.0L	4V	TCM(Transmission Control Module)			V	V	V				V			V	V	V	V											
Mercury	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)				V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)				V	V	V	V					V	V	V	V	V											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)				V	V	V																					
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)				V	V	V														V							
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)				V	V	V	V											V									
Mercury	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)				V		V	V																				
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)				V	V	V	V																				
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)				V		V	V																				
Mercury	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)				V	V	V	V																				
Mercury	FreestarMonterey	3.9L	GEM(Generic Electronic Module)				V	V	V	V														V						
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)				V	V	V	V																				
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)				V	V	V	V			V																	
Mercury	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)				V		V																					
Mercury	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)				V	V	V																					
Mercury	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)				V		V	V																				
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)				V	V	V	V													V							
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)				V	V	V																					
Mercury	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)				V		V	V																				
Mercury	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)				V		V	V																				
Mercury	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)				V	V	V	V																				
Mercury	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)				V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)				V	V	V	V					V	V	V	V	V											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)				V	V	V																					
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)				V	V	V														V							
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)				V	V	V	V											V									
Mercury	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)				V		V	V																				
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)				V	V	V	V																				
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)				V		V	V																				
Mercury	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)				V	V	V	V																				
Mercury	FreestarMonterey	4.2L	GEM(Generic Electronic Module)				V	V	V	V														V						
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)				V	V	V	V																				
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)				V	V	V	V			V																	
Mercury	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)				V		V																					
Mercury	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)				V	V	V																					
Mercury	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)				V		V	V																				
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)				V	V	V	V													V							
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)				V	V	V																					
Mercury	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)				V		V	V																				
Mercury	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)				V		V	V																				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)				V	V	V	V																				
Mercury	Mountaineer	2010 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.6L	PCM(Powertrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Mercury	Mountaineer	2010 MY	4.6L	TCM(Transmission Control Module)			V	V	V				V	V		V	V	V	V											
Mercury	Mountaineer	2010 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)			V	V	V				V																	
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Mountaineer	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Mercury	Mountaineer	2010 MY	4.6L	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Mercury	Mountaineer	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.6L	DSM(Driver's Seat Module)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Mercury	Mountaineer	2010 MY	4.6L	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	Mountaineer	2010 MY	4.6L	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.6L	PRB(Power Running Board)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V				V																	
Mercury	Mountaineer	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.0L	PCM(Powertrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Mercury	Mountaineer	2010 MY	4.0L	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.0L	ABS(Anti-Lock Brake System)			V	V	V												V	V								
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)			V	V	V				V																	
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Mountaineer	2010 MY	4.0L	DSM(Driver's Seat Module)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.0L	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.0L	GEM(Generic Electronic Module)			V	V	V	V			V											V						
Mercury	Mountaineer	2010 MY	4.0L	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.0L	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	Mountaineer	2010 MY	4.0L	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.0L	PRB(Power Running Board)			V	V	V	V			V																	
Mercury	Mountaineer	2010 MY	4.0L	RCM(Restraint Control Module)			V	V	V	V																				
Mercury	Mountaineer	2010 MY	4.0L	RETM(Rear Entertainment Module)			V	V	V				V																	
Mercury	Mountaineer	2010 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.6L	PCM(Powertrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	Mountaineer	2009 MY	4.6L	TCM(Transmission Control Module)			V	V	V				V	V		V	V	V	V											
Mercury	Mountaineer	2009 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)			V	V	V				V																	
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Mountaineer	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Mercury	Mountaineer	2009 MY	4.6L	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Mercury	Mountaineer	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.6L	DSM(Driver's Seat Module)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Mercury	Mountaineer	2009 MY	4.6L	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	Mountaineer	2009 MY	4.6L	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.6L	PRB(Power Running Board)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V				V																	
Mercury	Mountaineer	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.0L	PCM(Powertrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Mercury	Mountaineer	2009 MY	4.0L	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.0L	ABS(Anti-Lock Brake System)			V	V	V												V	V								
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)			V	V	V				V																	
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Mountaineer	2009 MY	4.0L	DSM(Driver's Seat Module)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.0L	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.0L	GEM(Generic Electronic Module)			V	V	V	V			V											V						
Mercury	Mountaineer	2009 MY	4.0L	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.0L	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	Mountaineer	2009 MY	4.0L	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.0L	PRB(Power Running Board)			V	V	V	V			V																	
Mercury	Mountaineer	2009 MY	4.0L	RCM(Restraint Control Module)			V	V	V	V																				
Mercury	Mountaineer	2009 MY	4.0L	RETM(Rear Entertainment Module)			V	V	V				V																	
Mercury	Mountaineer	2009 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.6L	PCM(Powertrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Mercury	Mountaineer	2008 MY	4.6L	TCM(Transmission Control Module)			V	V	V				V	V		V	V	V	V											
Mercury	Mountaineer	2008 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)			V	V	V				V																	
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Mountaineer	2008 MY	4.6L	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Mercury	Mountaineer	2008 MY	4.6L	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Mercury	Mountaineer	2008 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.6L	DSM(Driver's Seat Module)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Mercury	Mountaineer	2008 MY	4.6L	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	Mountaineer	2008 MY	4.6L	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.6L	PRB(Power Running Board)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V				V																	
Mercury	Mountaineer	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.0L	PCM(Powertrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Mercury	Mountaineer	2008 MY	4.0L	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.0L	ABS(Anti-Lock Brake System)			V	V	V												V	V								
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)			V	V	V				V																	
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Mountaineer	2008 MY	4.0L	DSM(Driver's Seat Module)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.0L	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.0L	GEM(Generic Electronic Module)			V	V	V	V			V											V						
Mercury	Mountaineer	2008 MY	4.0L	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.0L	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	Mountaineer	2008 MY	4.0L	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.0L	PRB(Power Running Board)			V	V	V	V			V																	
Mercury	Mountaineer	2008 MY	4.0L	RCM(Restraint Control Module)			V	V	V	V																				
Mercury	Mountaineer	2008 MY	4.0L	RETM(Rear Entertainment Module)			V	V	V				V																	
Mercury	Mountaineer	2008 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.6L	PCM(Powertrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Mercury	Mountaineer	2007 MY	4.6L	TCM(Transmission Control Module)			V	V	V				V	V		V	V	V	V											
Mercury	Mountaineer	2007 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)			V	V	V				V																	
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Mountaineer	2007 MY	4.6L	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	Mountaineer	2007 MY	4.6L	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Mercury	Mountaineer	2007 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.6L	DSM(Driver's Seat Module)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Mercury	Mountaineer	2007 MY	4.6L	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	Mountaineer	2007 MY	4.6L	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.6L	PRB(Power Running Board)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V				V																	
Mercury	Mountaineer	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.0L	PCM(Powertrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Mercury	Mountaineer	2007 MY	4.0L	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.0L	ABS(Anti-Lock Brake System)			V	V	V												V	V								
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)			V	V	V				V																	
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Mountaineer	2007 MY	4.0L	DSM(Driver's Seat Module)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.0L	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.0L	GEM(Generic Electronic Module)			V	V	V	V			V											V						
Mercury	Mountaineer	2007 MY	4.0L	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.0L	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	Mountaineer	2007 MY	4.0L	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.0L	PRB(Power Running Board)			V	V	V	V			V																	
Mercury	Mountaineer	2007 MY	4.0L	RCM(Restraint Control Module)			V	V	V	V																				
Mercury	Mountaineer	2007 MY	4.0L	RETM(Rear Entertainment Module)			V	V	V				V																	
Mercury	Mountaineer	2007 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.6L	PCM(Powertrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Mercury	Mountaineer	2006 MY	4.6L	TCM(Transmission Control Module)			V	V	V				V	V		V	V	V	V											
Mercury	Mountaineer	2006 MY	4.6L	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.6L	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)			V	V	V				V																	
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Mountaineer	2006 MY	4.6L	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Mercury	Mountaineer	2006 MY	4.6L	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Mercury	Mountaineer	2006 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.6L	DSM(Driver's Seat Module)			V	V	V	V			V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	Mountaineer	2006 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Mercury	Mountaineer	2006 MY	4.6L	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.6L	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	Mountaineer	2006 MY	4.6L	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.6L	PRB(Power Running Board)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.6L	RCM(Restraint Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.6L	RETM(Rear Entertainment Module)			V	V	V				V																	
Mercury	Mountaineer	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.0L	PCM(Powertrain Control Module)			V	V	V		V	V	V	V	V	V	V	V	V											
Mercury	Mountaineer	2006 MY	4.0L	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.0L	ABS(Anti-Lock Brake System)			V	V	V												V	V								
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)			V	V	V				V																	
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	Mountaineer	2006 MY	4.0L	DSM(Driver's Seat Module)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.0L	EATC(Electronic Automatic Temperature Control)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.0L	GEM(Generic Electronic Module)			V	V	V	V			V											V						
Mercury	Mountaineer	2006 MY	4.0L	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.0L	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	Mountaineer	2006 MY	4.0L	PAM(Parking Aid Module)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.0L	PRB(Power Running Board)			V	V	V	V			V																	
Mercury	Mountaineer	2006 MY	4.0L	RCM(Restraint Control Module)			V	V	V	V																				
Mercury	Mountaineer	2006 MY	4.0L	RETM(Rear Entertainment Module)			V	V	V				V																	
Mercury	Mountaineer	2006 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Mercury	Mountaineer	2003 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2003 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Mercury	Mountaineer	2003 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Mercury	Mountaineer	2003 MY	RCM(Restraint Control Module)				V	V	V	V													V							
Mercury	Mountaineer	2003 MY	RIM(Remote Immobilizer Module)				V	V	V	V													V							
Mercury	Mountaineer	2003 MY	GEM(Generic Electronic Module)				V	V	V	V													V							
Mercury	Mountaineer	2003 MY	PAM(Parking Aid Module)				V	V	V														V							
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)				V	V	V	V																				
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)				V	V	V																					
Mercury	Mountaineer	2002 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2002 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Mercury	Mountaineer	2002 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Mercury	Mountaineer	2002 MY	RCM(Restraint Control Module)				V	V	V	V													V							
Mercury	Mountaineer	2002 MY	RIM(Remote Immobilizer Module)				V	V	V	V													V							

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	Mountaineer	2002 MY	GEM(Generic Electronic Module)				V	V	V	V													V							
Mercury	Mountaineer	2002 MY	PAM(Parking Aid Module)				V	V	V														V							
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)				V	V	V	V																				
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)				V	V	V																					
Mercury	Mountaineer	2001 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2001 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Mercury	Mountaineer	2001 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Mercury	Mountaineer	2001 MY	RCM(Restraint Control Module)				V	V	V	V													V							
Mercury	Mountaineer	2001 MY	RIM(Remote Immobilizer Module)				V	V	V	V													V							
Mercury	Mountaineer	2001 MY	GEM(Generic Electronic Module)				V	V	V	V													V							
Mercury	Mountaineer	2001 MY	PAM(Parking Aid Module)				V	V	V														V							
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)				V	V	V	V																				
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)				V	V	V																					
Mercury	Mountaineer	2000 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2000 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Mercury	Mountaineer	2000 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Mercury	Mountaineer	2000 MY	RCM(Restraint Control Module)				V	V	V	V													V							
Mercury	Mountaineer	2000 MY	RIM(Remote Immobilizer Module)				V	V	V	V													V							
Mercury	Mountaineer	2000 MY	GEM(Generic Electronic Module)				V	V	V	V													V							
Mercury	Mountaineer	2000 MY	PAM(Parking Aid Module)				V	V	V														V							
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)				V	V	V	V																				
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)				V	V	V																					
Mercury	Mountaineer	1999 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1999 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Mercury	Mountaineer	1999 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Mercury	Mountaineer	1999 MY	RCM(Restraint Control Module)				V	V	V	V													V							
Mercury	Mountaineer	1999 MY	RIM(Remote Immobilizer Module)				V	V	V	V													V							
Mercury	Mountaineer	1999 MY	PAM(Parking Aid Module)				V	V	V														V							
Mercury	Mountaineer	1998 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1998 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Mercury	Mountaineer	1998 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Mercury	Mountaineer	1998 MY	RCM(Restraint Control Module)				V	V	V	V													V							
Mercury	Mountaineer	1998 MY	RIM(Remote Immobilizer Module)				V	V	V	V													V							
Mercury	Mountaineer	1997 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1997 MY	PCM(PowerTrain Control Module)				V	V	V	V																				
Mercury	Mountaineer	1997 MY	ABS(Anti-Lock Brake System)				V	V	V														V							
Mercury	Mountaineer	1997 MY	RCM(Restraint Control Module)				V	V	V														V							
Mercury	Mountaineer	1997 MY	RIM(Remote Immobilizer Module)				V	V	V	V													V							

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V				V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)			V	V	V		V																			
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)			V	V	V	V	V																			
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)			V	V	V		V																			
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)			V	V	V	V	V																			
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)			V	V	V	V	V																			
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)			V	V	V	V	V		V																	
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)			V	V	V							V	V	V	V											
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)			V	V	V				V																	
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)			V	V	V				V																	
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)			V	V					V																	
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)			V	V	V				V																	
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)			V	V	V				V																	
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)			V	V					V																	
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)			V	V	V		V		V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Vehicle Information	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Power balance	Key On Engine Off Self Test	Key On Engine Run Self Test	Reset KAM	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	TR Sensor Test Type	ABS Service Bleed	ABS Module Installation	ON-Demand Self test	Factory Keyless Entry Code	View Current Remote Trasmitter TIC	View Programmed Keyfobs	Reprogram a new Remote Transmitter	Erase One Remote Trasmitter	Erase All Remote Trasmitter	Pneumatic Test
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)			V	V	V	V	V	V	V	V	V	V	V	V	V	V										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)			V	V	V	V			V								V	V								
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)			V	V	V				V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)			V	V	V				V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)			V	V	V				V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)			V	V	V	V			V											V						
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)			V	V	V				V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)			V	V					V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)			V	V	V		V		V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)			V	V	V	V			V																	
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)			V	V	V	V																				
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Vehicle Info.	Vehicle Info.	Vehicle Info.																												
Ford	Crown Victoria	4.6L	2V	SYSTEM SEARCH																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	DDM(Driver's Door Module)																										
Ford	Crown Victoria	4.6L	2V	IC(Instrument Cluster)																										
Ford	Crown Victoria	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Crown Victoria	4.6L	2V	LCM(Lighting Control Module)																										
Ford	Crown Victoria	4.6L	2V	MC(Message Center)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	Crown Victoria	4.6L	2V	GEM(Generic Electronic Module)																										
Ford	Crown Victoria	4.6L	2V	VDM(Vehicle Dynamic Module)		V																								
Ford	Ecosport	1.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)			V	V																						
Ford	Ecosport	1.0L	ZETEC ROCAM	GEM(Generic Electronic Module)					V																					
Ford	Ecosport	1.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.4L	DIESEL	SYSTEM SEARCH																										
Ford	Ecosport	1.4L	DIESEL	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.4L	DIESEL	ABS(Anti-Lock Brake System)			V	V																						
Ford	Ecosport	1.4L	DIESEL	GEM(Generic Electronic Module)					V																					
Ford	Ecosport	1.4L	DIESEL	IC(Instrument Cluster)																										
Ford	Ecosport	1.4L	DIESEL	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)			V	V																						
Ford	Ecosport	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)					V																					
Ford	Ecosport	1.6L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	FFV	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Ecosport	1.6L	FFV	ABS(Anti-Lock Brake System)			V	V																						
Ford	Ecosport	1.6L	FFV	GEM(Generic Electronic Module)					V																					
Ford	Ecosport	1.6L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	TBM(Tracking And Blocking Module)						V	V	V																		
Ford	Ecosport	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)			V	V																						
Ford	Ecosport	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)					V																					
Ford	Ecosport	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)			V	V																						
Ford	Ecosport	2.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	FFV	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	FFV	ABS(Anti-Lock Brake System)			V	V																						
Ford	Ecosport	2.0L	FFV	GEM(Generic Electronic Module)					V																					
Ford	Ecosport	2.0L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	TBM(Tracking And Blocking Module)						V	V	V																		
Ford	Escort	2.0L	SYSTEM SEARCH																											
Ford	Escort	2.0L	PCM(PowerTrain Control Module)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ECS(Electronic Crash Sensor)																											
Ford	Escort	2.0L	PATS(Passive Anti Theft System)																											
Ford	Escort	2.0L	RAP(Remote Anti-Theft/Personality Module)																											
Ford	Edge	3.5L	4V	SYSTEM SEARCH																										
Ford	Edge	3.5L	4V	PCM(PowerTrain Control Module)									V																	
Ford	Edge	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Edge	3.5L	4V	ABS(Anti-Lock Brake System)										V																
Ford	Edge	3.5L	4V	ACM(Audio Control Module)											V															
Ford	Edge	3.5L	4V	ACM(Audio Control Module)											V	V	V	V	V											
Ford	Edge	3.5L	4V	APIM(Accessory Protocol Interface Module)																V	V									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Edge	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Edge	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	4V	IC(Instrument Cluster)																			V							
Ford	Edge	3.5L	4V	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																				V	V					
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																				V						
Ford	Edge	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	4V	RCM(Restraint Control Module)																						V				
Ford	Edge	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Edge	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Edge	3.5L	4V	SDARS(Satellite Digital Audio Receiver System)																	V									
Ford	Edge	3.5L	4V	TBM(Tracking And Blocking Module)						V	V	V																		
Ford	Edge	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.5L	TiVCT	PCM(PowerTrain Control Module)																							V	V		
Ford	Edge	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									V	
Ford	Edge	3.5L	TiVCT	ACM(Audio Control Module)											V															
Ford	Edge	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Edge	3.5L	TiVCT	BCM(Body Control Module)																		V								V
Ford	Edge	3.5L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	TiVCT	OCSM(Occupant Classification System Module)																				V	V					
Ford	Edge	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	TiVCT	RCM(Restraint Control Module)																						V				
Ford	Edge	3.5L	TiVCT	RFA(Remote Function Actuator)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Edge	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.5L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.5L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Edge	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.7L	TiVCT	PCM(PowerTrain Control Module)																							V	V		
Ford	Edge	3.7L	TiVCT	ABS(Anti-Lock Brake System)																									V	
Ford	Edge	3.7L	TiVCT	ACM(Audio Control Module)											V															
Ford	Edge	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Edge	3.7L	TiVCT	BCM(Body Control Module)																		V								V
Ford	Edge	3.7L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.7L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.7L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.7L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.7L	TiVCT	OCSM(Occupant Classification System Module)																				V	V					
Ford	Edge	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.7L	TiVCT	RCM(Restraint Control Module)																						V				
Ford	Edge	3.7L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Edge	3.7L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.7L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.7L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.7L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.7L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.7L	TiVCT	TBM(Tracking And Blocking Module)					V	V	V																			
Ford	Edge	3.7L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Escape	Up to 2004	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Escape	Up to 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	Up to 2004	Immobilizer																											
Ford	Escape	Up to 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	Up to 2004	RCM(Restraint Control Module)																											
Ford	Escape	Up to 2004	GEM(Generic Electronic Module)																											
Ford	Escape	From 2004	SYSTEM SEARCH																											
Ford	Escape	From 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	From 2004	PATS(Passive Anti Theft System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	RCM(Restraint Control Module)																											
Ford	Escape	From 2004	IC(Instrument cluster)																											
Ford	Escape	From 2004	GEM(Generic Electronic Module)						V																					
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																						V	V		
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																								V	
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)											V	V		V											
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																				V	V				
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																						V			
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																							V	V	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																								V	
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)											V	V		V											
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																			V	V						
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																						V				
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)										V																
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)											V	V	V	V	V											
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																							V	V		
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)										V																
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)												V		V												
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																V	V									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)												V														
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																				V						
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																						V				
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																							V	V		
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)										V																
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)												V		V												
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																V	V									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)												V														
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																				V						
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																						V				
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Excursion	GASOLINE	SYSTEM SEARCH																											
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											
Ford	Excursion	GASOLINE	ABS(Anti-Lock Brake System)																											
Ford	Excursion	GASOLINE	CSM(Central Security Module)																											
Ford	Excursion	GASOLINE	DSM(Driver's Seat Module)																											
Ford	Excursion	GASOLINE	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	GASOLINE	ECS(Electronic Crash Sensor)																											
Ford	Excursion	GASOLINE	GEM(Generic Electronic Module)																											
Ford	Excursion	GASOLINE	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	GASOLINE	OTC(Overhead Trip Computer)																											
Ford	Excursion	GASOLINE	PAM(Parking Aid Module)																											
Ford	Excursion	GASOLINE	PATS(Passive Anti Theft System)																											
Ford	Excursion	GASOLINE	TCM(Transmission Control Module)																											
Ford	Excursion	GASOLINE	VSM(Vehicle Security Module)																											
Ford	Excursion	DIESEL	SYSTEM SEARCH																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Excursion	DIESEL	CSM(Central Security Module)																											
Ford	Excursion	DIESEL	DSM(Driver's Seat Module)																											
Ford	Excursion	DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	DIESEL	ECS(Electronic Crash Sensor)																											
Ford	Excursion	DIESEL	GEM(Generic Electronic Module)																											
Ford	Excursion	DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	DIESEL	OTC(Overhead Trip Computer)																											
Ford	Excursion	DIESEL	PAM(Parking Aid Module)																											
Ford	Excursion	DIESEL	PATS(Passive Anti Theft System)																											
Ford	Excursion	DIESEL	TCM(Transmission Control Module)																											
Ford	Excursion	DIESEL	VSM(Vehicle Security Module)																											
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																					V	V			
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)									V																
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)										V	V	V	V	V											
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)										V	V		V												
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	APIM(Accessory Protocol Interface Module)															V	V									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																	V								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	EATC(Electronic Automatic Temperature Control)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	IC(Instrument Cluster)																		V							
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																			V						
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																				V					
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																				V					
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																			V						
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VDM(Vehicle Dynamic Module)	V																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VSM(Vehicle Security Module)																	V								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																					V	V			
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)									V																
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)										V	V	V	V	V											
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)										V	V		V												
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	APIM(Accessory Protocol Interface Module)															V	V									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																	V								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																		V							
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																		V							
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																			V						
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																				V					
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																				V					
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																			V						
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SDARS(Satellite Digital Audio Receiver System)															V										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TBC(Trailer Brake Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCCM(Transfer Case Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	VDM(Vehicle Dynamic Module)	V																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)									V																	
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)										V																
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	GEM(Generic Electronic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	5.4L	2V	IC(Instrument Cluster)																			V							
Ford	ExpeditionExpedition EL	5.4L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																						V				
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																				V						
Ford	ExpeditionExpedition EL	5.4L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VSM(Vehicle Security Module)																		V								
Ford	ExpeditionExpedition EL	4.6L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																							V	V		
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)										V																
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)											V	V	V	V	V											
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)											V	V		V												
Ford	ExpeditionExpedition EL	4.6L	2V	APIM(Accessory Protocol Interface Module)																V	V									
Ford	ExpeditionExpedition EL	4.6L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GPSM(Global Positioning System Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	4.6L	2V	IC(Instrument Cluster)																			V							
Ford	ExpeditionExpedition EL	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																				V						
Ford	ExpeditionExpedition EL	4.6L	2V	PRB(Power Running Board)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																						V				
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																				V						
Ford	ExpeditionExpedition EL	4.6L	2V	RCU(Audio Rear Control Unit)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RETM(Rear Entertainment Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SDARS(Satellite Digital Audio Receiver System)																	V									
Ford	ExpeditionExpedition EL	4.6L	2V	TCM(Transmission Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)		V																								
Ford	ExpeditionExpedition EL	4.6L	2V	4X4(4x4 Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VSM(Vehicle Security Module)																		V								
Ford	Explorer	2015 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																						V	V		
Ford	Explorer	2015 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																								V	
Ford	Explorer	2015 MY	3.5L	TiVCT	ACM(Audio Control Module)										V															
Ford	Explorer	2015 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer	2015 MY	3.5L	TiVCT	BCM(Body Control Module)																	V								V
Ford	Explorer	2015 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2015 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																		V	V						
Ford	Explorer	2015 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RCM(Restraint Control Module)																				V					
Ford	Explorer	2015 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																					V	V			
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																							V		
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)									V																
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																V									V
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																		V	V						
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																					V	V			
Ford	Explorer	2014 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																							V		
Ford	Explorer	2014 MY	3.5L	TiVCT	ACM(Audio Control Module)										V															
Ford	Explorer	2014 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer	2014 MY	3.5L	TiVCT	BCM(Body Control Module)																	V								V
Ford	Explorer	2014 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2014 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																			V	V					
Ford	Explorer	2014 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RCM(Restraint Control Module)																					V				
Ford	Explorer	2014 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																						V	V		
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																								V	
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)										V															
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																	V								V
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																			V	V					
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																					V	V			
Ford	Explorer	2013 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																							V		
Ford	Explorer	2013 MY	3.5L	TiVCT	ACM(Audio Control Module)										V															
Ford	Explorer	2013 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer	2013 MY	3.5L	TiVCT	BCM(Body Control Module)																	V								V
Ford	Explorer	2013 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																			V	V					
Ford	Explorer	2013 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RCM(Restraint Control Module)																					V				
Ford	Explorer	2013 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PATS(Passive Anti Theft System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																					V	V		
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																							V	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)										V														
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																V								V
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																		V	V					
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	SYSTEM SEARCH																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2012 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																						V	V		
Ford	Explorer	2012 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																								V	
Ford	Explorer	2012 MY	3.5L	TiVCT	ACM(Audio Control Module)										V															
Ford	Explorer	2012 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer	2012 MY	3.5L	TiVCT	BCM(Body Control Module)																	V								V
Ford	Explorer	2012 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																			V	V					
Ford	Explorer	2012 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RCM(Restraint Control Module)																					V				
Ford	Explorer	2012 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																						V	V		
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																								V	
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)										V															
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																	V								V

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																		V	V						
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																					V	V			
Ford	Explorer	2011 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																							V		
Ford	Explorer	2011 MY	3.5L	TiVCT	ACM(Audio Control Module)										V															
Ford	Explorer	2011 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer	2011 MY	3.5L	TiVCT	BCM(Body Control Module)																	V								V
Ford	Explorer	2011 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																			V	V					
Ford	Explorer	2011 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RCM(Restraint Control Module)																					V				
Ford	Explorer	2011 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																					V	V			
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																							V		
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)									V																
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																V									V
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																		V	V						
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)										V															
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)				V																					
Ford	Explorer	2010 MY	4.0L	2V	IC(Instrument Cluster)																		V							
Ford	Explorer	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.0L	2V	RCM(Restraint Control Module)																				V					
Ford	Explorer	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2010 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer	2010 MY	4.6L	3V	ACM(Audio Control Module)											V		V												
Ford	Explorer	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)				V																					
Ford	Explorer	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.6L	3V	RCM(Restraint Control Module)																				V					
Ford	Explorer	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)										V															
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)				V																					
Ford	Explorer	2009 MY	4.0L	2V	IC(Instrument Cluster)																		V							
Ford	Explorer	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.0L	2V	RCM(Restraint Control Module)																				V					
Ford	Explorer	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2009 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer	2009 MY	4.6L	3V	ACM(Audio Control Module)											V		V												
Ford	Explorer	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)				V																					
Ford	Explorer	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.6L	3V	RCM(Restraint Control Module)																				V					
Ford	Explorer	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.0L	2V	GEM(Generic Electronic Module)				V																					
Ford	Explorer	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.0L	2V	RCM(Restraint Control Module)																				V					
Ford	Explorer	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)									V																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.6L	3V	GEM(Generic Electronic Module)				V																					
Ford	Explorer	2008 MY	4.6L	3V	IC(Instrument Cluster)																		V							
Ford	Explorer	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.6L	3V	RCM(Restraint Control Module)																				V					
Ford	Explorer	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)															V										
Ford	Explorer	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.0L	2V	GEM(Generic Electronic Module)				V																					
Ford	Explorer	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.0L	2V	RCM(Restraint Control Module)																				V					
Ford	Explorer	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)															V										
Ford	Explorer	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.6L	3V	GEM(Generic Electronic Module)				V																					
Ford	Explorer	2007 MY	4.6L	3V	IC(Instrument Cluster)																		V							
Ford	Explorer	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																			V						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.6L	3V	RCM(Restraint Control Module)																				V					
Ford	Explorer	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.0L	2V	GEM(Generic Electronic Module)				V																					
Ford	Explorer	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.0L	2V	RCM(Restraint Control Module)																				V					
Ford	Explorer	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.6L	3V	GEM(Generic Electronic Module)				V																					
Ford	Explorer	2006 MY	4.6L	3V	IC(Instrument Cluster)																		V							
Ford	Explorer	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.6L	3V	RCM(Restraint Control Module)																				V					
Ford	Explorer	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer	2005 MY	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2005 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2005 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2005 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2005 MY	RCM(Restraint Control Module)																					V						
Ford	Explorer	2005 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2004 MY	SYSTEM SEARCH																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2004 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2004 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2004 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2004 MY	RCM(Restraint Control Module)																					V						
Ford	Explorer	2004 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2003 MY	SYSTEM SEARCH																											
Ford	Explorer	2003 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2003 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2003 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2003 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2003 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2003 MY	RCM(Restraint Control Module)																					V						
Ford	Explorer	2003 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2002 MY	SYSTEM SEARCH																											
Ford	Explorer	2002 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2002 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2002 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2002 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2002 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2002 MY	RCM(Restraint Control Module)																					V						
Ford	Explorer	2002 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2001 MY	SYSTEM SEARCH																											
Ford	Explorer	2001 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2001 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2001 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2001 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer	2001 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2001 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	SYSTEM SEARCH																											
Ford	Explorer	2000 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2000 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2000 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	2000 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2000 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	1999 MY	SYSTEM SEARCH																											
Ford	Explorer	1999 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1999 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1999 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1999 MY	PAM(Parking Aid Module)																											
Ford	Explorer	1998 MY	SYSTEM SEARCH																											
Ford	Explorer	1998 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1998 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1998 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1998 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1997 MY	SYSTEM SEARCH																											
Ford	Explorer	1997 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1997 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1997 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1997 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)										V															
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer SportTrac	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)				V																					
Ford	Explorer SportTrac	2010 MY	4.0L	2V	IC(Instrument Cluster)																		V							
Ford	Explorer SportTrac	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RCM(Restraint Control Module)																				V					
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ACM(Audio Control Module)											V		V												
Ford	Explorer SportTrac	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)				V																					
Ford	Explorer SportTrac	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RCM(Restraint Control Module)																				V					
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)										V															
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer SportTrac	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)				V																					
Ford	Explorer SportTrac	2009 MY	4.0L	2V	IC(Instrument Cluster)																		V							
Ford	Explorer SportTrac	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RCM(Restraint Control Module)																				V					
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)															V										
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ACM(Audio Control Module)											V		V												
Ford	Explorer SportTrac	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)				V																					
Ford	Explorer SportTrac	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RCM(Restraint Control Module)																				V					
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)															V										
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																			V						
Ford	Explorer SportTrac	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	GEM(Generic Electronic Module)				V																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer SportTrac	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RCM(Restraint Control Module)																				V					
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)															V										
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	GEM(Generic Electronic Module)				V																					
Ford	Explorer SportTrac	2008 MY	4.6L	3V	IC(Instrument Cluster)																		V							
Ford	Explorer SportTrac	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RCM(Restraint Control Module)																				V					
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)															V										
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																			V						
Ford	Explorer SportTrac	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	GEM(Generic Electronic Module)				V																					
Ford	Explorer SportTrac	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RCM(Restraint Control Module)																				V					
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	GEM(Generic Electronic Module)				V																					
Ford	Explorer SportTrac	2007 MY	4.6L	3V	IC(Instrument Cluster)																		V							
Ford	Explorer SportTrac	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RCM(Restraint Control Module)																				V					
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																			V						
Ford	Explorer SportTrac	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)									V																
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	GEM(Generic Electronic Module)				V																					
Ford	Explorer SportTrac	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RCM(Restraint Control Module)																				V					
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)									V																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	GEM(Generic Electronic Module)				V																					
Ford	Explorer SportTrac	2006 MY	4.6L	3V	IC(Instrument Cluster)																		V							
Ford	Explorer SportTrac	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																			V						
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RCM(Restraint Control Module)																				V					
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	E-Series	5.4L	2V	2004 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																		V							
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	RAP(Remote Anti-Theft/Personality Module)																									
Ford	E-Series	5.4L	2V	2004 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2004 ~	VSM(Vehicle Security Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2009 ~	ACM(Audio Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	E-Series	5.4L	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																	V								
Ford	E-Series	5.4L	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	E-Series	5.4L	2V	2009 ~	IPC(Instrument Panel Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	E-Series	5.4L	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																						V	V			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																V	V									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																		V								V
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																				V	V					
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																						V				
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																										
Ford	F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																V	V									
Ford	F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																		V								V
Ford	F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																				V	V					
Ford	F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																						V				
Ford	F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																										
Ford	F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																					V	V		
Ford	F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)											V		V											
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																V								
Ford	F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																	V							
Ford	F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																		V	V					
Ford	F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																				V				
Ford	F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)								V																
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																		V							
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																			V						
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																			V						
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																									
Ford	F150	4.6L(BETA)	3V	SYSTEM SEARCH																										
Ford	F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																							V	V		
Ford	F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																										
Ford	F150	4.6L(BETA)	3V	ACM(Audio Control Module)												V		V												
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																										
Ford	F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																										
Ford	F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																										
Ford	F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	4.6L(BETA)	3V	IC(Instrument Cluster)																			V							
Ford	F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																										
Ford	F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																				V	V					
Ford	F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																										
Ford	F150	4.6L(BETA)	3V	PRB(Power Running Board)																										
Ford	F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																						V				
Ford	F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																										
Ford	F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																										
Ford	F150	5.0L	TiVCT	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	F150	5.0L	TiVCT	PCM(Powertrain Control Module)																							V	V		
Ford	F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	5.0L	TiVCT	ACM(Audio Control Module)												V		V												
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	5.0L	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	5.0L	TiVCT	IC(Instrument Cluster)																										
Ford	F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																				V	V					
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PRB(Power Running Board)																										
Ford	F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	5.0L	TiVCT	RCM(Restraint Control Module)																						V				
Ford	F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	5.0L	TiVCT	TCM(Transmission Control Module)																										
Ford	F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	F150	5.4L	3V	2009 ~	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																						V			
Ford	F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)															V	V									
Ford	F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																	V								
Ford	F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																		V							
Ford	F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																			V	V					
Ford	F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2009 ~	PRB(Power Running Board)																									
Ford	F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																					V				
Ford	F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)								V																	
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																		V							
Ford	F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																			V						
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																			V						
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	6.2L(BETA)	2V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																										
Ford	F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																										
Ford	F150	6.2L(BETA)	2V	ACM(Audio Control Module)												V		V												
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																										
Ford	F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																										
Ford	F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																										
Ford	F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																										
Ford	F150	6.2L(BETA)	2V	IC(Instrument Cluster)																			V							
Ford	F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																										
Ford	F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																				V	V					
Ford	F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																										
Ford	F150	6.2L(BETA)	2V	PRB(Power Running Board)																										
Ford	F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																						V				
Ford	F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																										
Ford	F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																										
Ford	F150	Other	2004 ~ 2008	SYSTEM SEARCH																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)									V																	
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																										
Ford	F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																										
Ford	F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																										
Ford	F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	Other	2004 ~ 2008	IC(Instrument Cluster)																			V							
Ford	F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																				V						
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																				V						
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										
Ford	F250	7.3L	SYSTEM SEARCH																											
Ford	F250	7.3L	PCM(PowerTrain Control Module)																											
Ford	F250	7.3L	ABS(Anti-Lock Brake System)																											
Ford	F250	7.3L	ECS(Electronic Crash Sensor)																											
Ford	F250	7.3L	GEM(Generic Electronic Module)																											
Ford	F250	6.2L	SYSTEM SEARCH																											
Ford	F250	6.2L	PCM(Powertrain Control Module)																							V	V			
Ford	F250	6.2L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.2L	ACM(Audio Control Module)												V	V		V												
Ford	F250	6.2L	APIM(Accessory Protocol Control Module)																	V	V									
Ford	F250	6.2L	BCMii(Body Control Module)																											V
Ford	F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																											
Ford	F250	6.2L	DSM(Driver Seat Module)																											
Ford	F250	6.2L	GPSM(Global Positioning System Module)																											
Ford	F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F250	6.2L	IPC(Instrument Panel Control Module)																											
Ford	F250	6.2L	PAM(Parking Aid Module)																											
Ford	F250	6.2L	RCM(Restraint Control Module)																							V				
Ford	F250	6.2L	SCCM(Streering Colume Control Module)																											
Ford	F250	6.2L	TBC(Trailer Brake Control Module)																											
Ford	F250	6.2L	TCCM(Transfer Case Control Module)																											
Ford	F250	6.2L	TPM(Tire Pressure Monitor)																											
Ford	F250	6.0L	SYSTEM SEARCH																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.0L	GEM(Generic Electronic Module)																											
Ford	F250	6.0L	HEC(Hybrid Electrical Cluster)																											
Ford	F250	6.0L	OTC(Overhead Trip Computer)																											
Ford	F250	6.0L	PAM(Parking Aid Module)																											
Ford	F250	6.0L	PATS(Passive Anti Theft System)																											
Ford	F250	6.0L	RCM(Restraint Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	VSM(Vehicle Security Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SYSTEM SEARCH																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM(PowerTrain Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4(4x4 Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS(Anti-Lock Brake System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM(Audio Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM(Auxiliary Heater Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM(Accessory Protocol Interface Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM(Circuit Deactivation Ignition Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM(Driver's Seat Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GPSM(Global Positioning System Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC(Instrument Cluster)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM(Parking Aid Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM(Restraint Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM(Rear Entertainment Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS(Satellite Digital Audio Receiver System)																	V									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC(Trailer Brake Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM(Transmission Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																							V		
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																									V
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																					V				
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																						V			
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																									V
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																					V				
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)															V										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																									
Ford	Fiesta	1.4L	DURATEC 16V	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																						V				
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	GEM(Generic Electronic Module)					V																					
Ford	Fiesta	1.4L	DURATEC 16V	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V																						
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Fiesta	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)			V	V																						
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																						V				
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)					V																					
Ford	Fiesta	1.6L	DURATEC	BCMii(Body Control Module)																										
Ford	Fiesta	1.6L	DURATEC	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																							V	V		
Ford	Fiesta	1.6L	TiVCT	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																									V	
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	BCM(Body Control Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Fiesta	1.6L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																				V	V					
Ford	Fiesta	1.6L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RCM(Restraint Control Module)																						V				
Ford	Fiesta	1.6L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.6L	TiVCT	VSM(Vehicle Security Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	ABS(Anti-Lock Brake System)			V	V																						
Ford	Fiesta	1.6L	Zetec Rocam	IC(Instrument Cluster)																										
Ford	Fiesta	1.6L	Zetec Rocam	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	RKE(Remote Keyless Entry)					V																					
Ford	Fiesta	1.6L	Zetec Rocam	TCM(Transmission Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	SYSTEM SEARCH																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)			V	V																						
Ford	Fiesta	2.0L	SYSTEM SEARCH																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)				V	V																						
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	2.0L	ACM(Audio Control Module)																											
Ford	Fiesta	2.0L	EATC(Electronic Automatic Temperature Control)																											
Ford	Fiesta	2.0L	GEM(Generic Electronic Module)																											
Ford	Fiesta	2.0L	IC(Instrument Cluster)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	RCM(Restraint Control Module)																											
Ford	Fiesta	2.0L	PATS(Passive Anti Theft System)-BETA																											
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V																						
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																			V							
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Focus	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	ZETEC ROCAM	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)					V																					
Ford	Focus	1.6L	ZETEC ROCAM	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Focus	1.6L	ZETEC ROCAM	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																			V							
Ford	Focus	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																						V				
Ford	Focus	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Focus	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic power steering)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																						V				
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ACM(Audio control module)																										
Ford	Focus	1.8L	DURATEC HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.8L	DURATEC HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.8L	DURATEC HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.8L	DURATEC HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.8L	DURATEC HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	IC(Instrument cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	NAV(Navigation System)																										
Ford	Focus	1.8L	DURATEC HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	MC(Message Center)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																							V	V		
Ford	Focus	2.0L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)										V																
Ford	Focus	2.0L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)					V																					
Ford	Focus	2.0L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																				V						
Ford	Focus	2.0L DURATEC HE/I4	2008~	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																							V	V		
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ABS(Anti-Lock Brake System)										V																
Ford	Focus	2.0L DURATEC HE/I4	2008~	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Focus	2.0L DURATEC HE/I4	2008~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FDIM(Front Display Interface Module)												V														
Ford	Focus	2.0L DURATEC HE/I4	2008~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Focus	2.0L DURATEC HE/I4	2008~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	OCSM(Occupant Classification System Module)																				V						
Ford	Focus	2.0L DURATEC HE/I4	2008~	RCM(Restraint Control Module)																						V				
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TCM(Transmission control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CSM(Central Security Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EPS(Electronic power steering)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GDM(Generic Display Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	IC(Instrument cluster)																			V							
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	NAV(Navigation System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RKE(Remote Keyless Entry)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TBM(Tracking And Blocking Module)						V	V	V																		
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SRM(Speech recognition module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SYSTEM SEARCH																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PCM(PowerTrain Control Module)																							V	V		
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ABS(Anti-Lock Brake System)																									V	
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ACM(Audio Control Module)											V	V		V												
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	BCM(Body Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DDM(Driver's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	IPC(Instrument Panel Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PAM(Parking Aid Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PSCM(Power Steering Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RCM(Restraint Control Module)																						V				
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SASM(Steering Angle Sensor Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Focus	2.0L DIESEL	2003 ~ 2008	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FACM(Fuel Additive Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	IC(Instrument cluster)																			V							
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RCM(Restraint Control Module)																						V				
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RETM(Rear Entertainment Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RKE(Remote Keyless Entry)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																							V	V		
Ford	Focus	2.3L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)										V																
Ford	Focus	2.3L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)					V																					
Ford	Focus	2.3L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																				V						
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	TCM(Transmission control module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	DDM(Driver's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	MC(Message Center)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ACM(Audio control module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																						V				
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																			V							
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																						V				
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Focus C-MAX	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	IC(Instrument Cluster)																			V							
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RCM(Restraint Control Module)																						V				
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																			V							
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																						V				
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Flex	3.5L	4V	SYSTEM SEARCH																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	4V	ACM(Audio control module)																										
Ford	Flex	3.5L	4V	APIM(Accessory Protocol Interface Module)														V												
Ford	Flex	3.5L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	4V	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Flex	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	4V	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	4V	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	4V	IC(Instrument cluster)																										
Ford	Flex	3.5L	4V	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	4V	LTM(Liftgate/Trunk Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Flex	3.5L	4V	OCSM(Occupant Classification System Module)																				V	V					
Ford	Flex	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	4V	Factory Keyless Entry Code																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																						V	V			
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio control module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)														V												
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC(Instrument cluster)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																				V	V					
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Flex	3.5L	TiVCT	PCM(PowerTrain Control Module)																						V	V			
Ford	Flex	3.5L	TiVCT	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Flex	3.5L	TiVCT	ACM(Audio control module)																										
Ford	Flex	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)														V												
Ford	Flex	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	TiVCT	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Flex	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	TiVCT	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	TiVCT	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	TiVCT	IC(Instrument cluster)																										
Ford	Flex	3.5L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	TiVCT	OCSM(Occupant Classification System Module)																				V	V					
Ford	Flex	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	TiVCT	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																					V						
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																					V						
Ford	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Ford	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Ford	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																					V						
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																					V						
Ford	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Ford	Freestyle	3.0L	4V	SYSTEM SEARCH																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Freestyle	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Freestyle	3.0L	4V	ACM(Audio Control Module)										V																
Ford	Freestyle	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Freestyle	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Freestyle	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Freestyle	3.0L	4V	IC(Instrument Cluster)																			V							
Ford	Freestyle	3.0L	4V	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Freestyle	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Freestyle	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Five Hundred	3.0L	4V	SYSTEM SEARCH																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Five Hundred	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Five Hundred	3.0L	4V	ACM(Audio Control Module)											V															
Ford	Five Hundred	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Five Hundred	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Five Hundred	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Five Hundred	3.0L	4V	IC(Instrument Cluster)																			V							
Ford	Five Hundred	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Five Hundred	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Five Hundred	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Ford GT	5.4L	4V	SYSTEM SEARCH																										
Ford	Ford GT	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																		V								
Ford	Ford GT	5.4L	4V	IC(Instrument Cluster)																										
Ford	Ford GT	5.4L	4V	PATS(Passive Anti Theft System)																										
Ford	Ford GT	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)			V	V																						
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	TCM(Transmission control module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Fusion	1.6L	DURATEC	ABS(Anti-Lock Brake System)			V	V																						
Ford	Fusion	1.6L	DURATEC	IC(Instrument cluster)																										
Ford	Fusion	1.6L	DURATEC	ACM(Audio control module)																										
Ford	Fusion	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fusion	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																						V	V			
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										V
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																					V					
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																						V	V			
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										V
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																					V					
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SYSTEM SEARCH																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																								V		
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BCM(Body Control Module)																										V
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HUD(Head Up Display)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM(Secondary OBD Control Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	TCU(Telematic Control Unit Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																							V	V		
Ford	Fusion	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)										V																
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)											V	V		V												
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Fusion	2.3L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																				V						
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																				V	V					
Ford	Fusion	2.3L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																						V				
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)					V	V	V																			
Ford	Fusion	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																	V									
Ford	Fusion	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																							V			
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Fusion	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)										V																
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)											V	V		V												
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)											V	V		V												
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Fusion	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																				V	V					
Ford	Fusion	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																				V	V	V				
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)						V	V	V																		
Ford	Fusion	2.5L	IVCT	SYSTEM SEARCH																										
Ford	Fusion	2.5L	IVCT	PCM(PowerTrain Control Module)																							V			
Ford	Fusion	2.5L	IVCT	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	IVCT	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Fusion	2.5L	IVCT	BCM(Body Control Module)																		V								V
Ford	Fusion	2.5L	IVCT	C-CM(Cruise Control Module)																										
Ford	Fusion	2.5L	IVCT	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.5L	IVCT	DDM(Driver's Door Module)																										
Ford	Fusion	2.5L	IVCT	DSM(Driver's Seat Module)																										
Ford	Fusion	2.5L	IVCT	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	IVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.5L	IVCT	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	IVCT	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	IVCT	GWM(Gateway Module A)																										
Ford	Fusion	2.5L	IVCT	HUD(Head Up Display)																										
Ford	Fusion	2.5L	IVCT	IPC(Instrument Panel Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Fusion	2.5L	IVCT	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.5L	IVCT	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	IVCT	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	IVCT	PDM(Passenger's Door Module)																										
Ford	Fusion	2.5L	IVCT	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	IVCT	RACM(Rear Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	RCM(Restraint Control Module)																						V				
Ford	Fusion	2.5L	IVCT	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.5L	IVCT	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.5L	IVCT	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.5L	IVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	IVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																							V	V		
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)											V	V		V												
Ford	Fusion	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																				V	V					
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)						V	V	V																		
Ford	Fusion	3.0L	4V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																							V			
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.0L	4V	ABS(Anti-Lock Brake System)										V																
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)											V	V		V												
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Fusion	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																				V						
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																				V	V					
Ford	Fusion	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																						V				
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.0L	4V	TBM(Tracking And Blocking Module)					V	V	V																			
Ford	Fusion	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																	V									
Ford	Fusion	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Fusion	3.5L	4V	SYSTEM SEARCH																										
Ford	Fusion	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.5L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.5L	4V	ABS(Anti-Lock Brake System)										V																
Ford	Fusion	3.5L	4V	ACM(Audio Control Module)											V	V		V												
Ford	Fusion	3.5L	4V	APIM(Accessory Protocol Interface Module)																V	V									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Fusion	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.5L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.5L	4V	OCSM(Occupant Classification System Module)																				V	V					
Ford	Fusion	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.5L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.5L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.5L	4V	TBM(Tracking And Blocking Module)						V	V	V																		
Ford	KA	2000 MY	SYSTEM SEARCH																											
Ford	KA	2000 MY	PCM(PowerTrain Control Module)																											
Ford	KA	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	KA	2000 MY	RCM(Restraint Control Module)																											
Ford	KA	1999 MY	PCM(PowerTrain Control Module)																											
Ford	KA	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																							V	V		
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									V	
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)											V	V		V												
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																				V	V					
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																						V				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																							V	V		
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									V	
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)											V	V		V												
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																				V	V					
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																						V				
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Kuga	2.0L DIESEL	SYSTEM SEARCH																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Kuga	2.0L DIESEL	TCM(Transmission Control Module)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																											
Ford	Kuga	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																											
Ford	Kuga	2.0L DIESEL	AWD(All Wheel Drive Module)																											
Ford	Kuga	2.0L DIESEL	BCMii(Body Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Kuga	2.0L DIESEL	CCMii(Cruise Control Module)																											
Ford	Kuga	2.0L DIESEL	CMR(Camera Module Rear)																											
Ford	Kuga	2.0L DIESEL	D_DCU(Driver Door Control Unit)																											
Ford	Kuga	2.0L DIESEL	DDM(Driver's Door Module)																											
Ford	Kuga	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Kuga	2.0L DIESEL	EPS(Electronic Power Steering)																											
Ford	Kuga	2.0L DIESEL	FDSM(Front Distance Sensing Module)																											
Ford	Kuga	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																											
Ford	Kuga	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Kuga	2.0L DIESEL	GEM(Generic Electronic Module)																											
Ford	Kuga	2.0L DIESEL	GPSM(Global Positioning System Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Kuga	2.0L DIESEL	IPM-A(Image Processing Module A)																											
Ford	Kuga	2.0L DIESEL	IPM-B(Image Processing Module B)																											
Ford	Kuga	2.0L DIESEL	IPC(Instrument Panel Control Module)																											
Ford	Kuga	2.0L DIESEL	IC(Instrument Cluster)																				V							
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PSCM(Power Steering Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																							V				
Ford	Kuga	2.0L DIESEL	RFA(Remote Function Actuator)																											
Ford	Kuga	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																											
Ford	Kuga	2.0L DIESEL	RETM(Rear Entertainment Module)																											
Ford	Kuga	2.0L DIESEL	SASM(Steering Angle Sensor Module)																											
Ford	Kuga	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Kuga	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Kuga	2.0L DIESEL	SRM(Speech Recognition Module)																											
Ford	Kuga	2.0L DIESEL	TRM(Trailer Module)																											
Ford	Kuga	2.5L	I5	SYSTEM SEARCH																										
Ford	Kuga	2.5L	I5	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.5L	I5	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.5L	I5	ACM(Audio Control Module)																										
Ford	Kuga	2.5L	I5	AWD(All Wheel Drive Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Kuga	2.5L	I5	CMR(Camera Module Rear)																										
Ford	Kuga	2.5L	I5	D_DCU(Driver Door Control Unit)																										
Ford	Kuga	2.5L	I5	EATC(Electronic Automatic Temperature Control)																										
Ford	Kuga	2.5L	I5	EPS(Electronic Power Steering)																										
Ford	Kuga	2.5L	I5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Kuga	2.5L	I5	GEM(Generic Electronic Module)																										
Ford	Kuga	2.5L	I5	HCM(Headlamp Control Module)																										
Ford	Kuga	2.5L	I5	IC(Instrument Cluster)																			V							
Ford	Kuga	2.5L	I5	PAM(Parking Aid Module)																										
Ford	Kuga	2.5L	I5	PDM(Passenger's Door Module)																										
Ford	Kuga	2.5L	I5	RCM(Restraint Control Module)																										
Ford	Kuga	2.5L	I5	RETM(Rear Entertainment Module)																										
Ford	Kuga	2.5L	I5	RKE(Remote Keyless Entry)																										
Ford	Kuga	2.5L	I5	SRM(Speech Recognition Module)																										
Ford	Kuga	2.5L	I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Mondeo	2010 MY	2.5L I5	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.5L I5	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.5L I5	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.5L I5	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.5L I5	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.5L I5	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.5L I5	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.5L I5	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SYSTEM SEARCH																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	AHCM(Auxiliary Heater Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	BCMii(Body Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CCMii(Cruise Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DDM(Driver's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DSM(Driver's Seat Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HCM(HeadLamp Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RFA(Remote Function Actuator)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TRM(Trailer Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	GEM(Generic Electronic Module)				V																						
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ACM(Audio Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	CDP(Compact Disc Player)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GDM(Generic Display Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GEM(Generic Electronic Module)				V																						
Ford	Mondeo	2003 MY	3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	NAV(Navigation System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SRM(Speech Recognition Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	SYSTEM SEARCH																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	GEM(Generic Electronic Module)					V																					
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	HCM(Headlamp Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2000 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	2000 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	2000 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1999 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1999 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Mondeo	1998 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1998 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1998 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1997 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1997 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1997 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1997 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																							V	V		
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)											V	V		V												
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	BCM-B(Body Control Module B)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Mustang	3.7L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Mustang	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Mustang	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Mustang	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Mustang	3.7L	TiVCT	OCSM(Occupant Classification System Module)																				V						
Ford	Mustang	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Mustang	3.7L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																						V				
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																				V						
Ford	Mustang	3.8L	SYSTEM SEARCH																											
Ford	Mustang	3.8L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.8L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.8L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.8L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.8L	RCM(Restraint Control Module)																											
Ford	Mustang	3.9L	SYSTEM SEARCH																											
Ford	Mustang	3.9L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.9L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.9L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.9L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.9L	RCM(Restraint Control Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																							V	V		
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)											V	V		V												
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	BCM-B(Body Control Module B)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)					V																					
Ford	Mustang	4.0L	V6 (SOHC)	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.0L	V6 (SOHC)	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	IC(Instrument Cluster)																			V							
Ford	Mustang	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																				V						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Mustang	4.0L	V6 (SOHC)	PAM(Parking Aid Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PSCM(Power Steering Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																					V					
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																				V						
Ford	Mustang	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																	V									
Ford	Mustang	4.0L	V6 (SOHC)	PATS(Passive Anti Theft System)-BETA																										
Ford	Mustang	4.6L	3V	SYSTEM SEARCH																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																							V	V		
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)											V	V		V												
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	BCM-B(Body Control Module B)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																			V							
Ford	Mustang	4.6L	3V	OCSM(Occupant Classification System Module)																				V						
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																						V				
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																				V						
Ford	Mustang	4.6L	3V	PATS(Passive Anti Theft System)-BETA																										
Ford	Mustang	5.0L	~ 2014	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																						V	V		
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)										V	V		V												
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)															V	V									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FDIM(Front Display Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																V									
Ford	Mustang	5.0L	~ 2014	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	OCSM(Occupant Classification System Module)																		V							
Ford	Mustang	5.0L	~ 2014	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																				V					
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																		V							
Ford	Mustang	5.0L	2015 ~	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PCM(PowerTrain Control Module)																					V	V			
Ford	Mustang	5.0L	2015 ~	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM(Body Control Module)																									V
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	C-CM(Cruise Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DACM-C(Digital Audio Control Module C)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DDM(Driver's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSM(Driver's Seat Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GWM(Gateway Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	HUD(Head Up Display)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ICM(Information Center Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-A(Movable Roof Control Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-B(Movable Roof Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PAM(Parking Aid Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PDM(Passenger's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Mustang	5.0L	2015 ~	TiVCT	RCM(Restraint Control Module)																					V				
Ford	Mustang	5.0L	2015 ~	TiVCT	RTM(Radio Transceiver Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCM-E(Seat Control Module E)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Mustang	5.4L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																							V	V		
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)											V	V		V												
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	BCM-B(Body Control Module B)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.4L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Mustang	5.4L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.4L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.4L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.4L	4V	OCSM(Occupant Classification System Module)																				V						
Ford	Mustang	5.4L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																						V				
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																				V						
Ford	Mustang	5.8L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																							V	V		
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)											V	V		V												
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	BCM-B(Body Control Module B)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.8L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Mustang	5.8L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.8L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.8L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.8L	4V	OCSM(Occupant Classification System Module)																				V						
Ford	Mustang	5.8L	4V	PAM(Parking Aid Module)																										
Ford	Mustang	5.8L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																						V				
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																				V						
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																							V	V		
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										V
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM-B(Body Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ICM(Information Center Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-A(Movable Roof Control Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-B(Movable Roof Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																						V				
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)											V															
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																						V				
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)					V	V	V																			
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Diesel(WL-CD)	SYSTEM SEARCH																											
Ford	Ranger	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.0 Diesel(WE-CD)	SYSTEM SEARCH																											
Ford	Ranger	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Ranger	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																					V					
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)						V	V	V																		
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	GEM(Generic Electronic Module)					V																					
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																				V						
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																					V					
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																	V									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Gasoline	SYSTEM SEARCH																											
Ford	Ranger	2.5 Gasoline	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Gasoline	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Gasoline	ACM(Audio Control Module)												V															

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Ranger	2.5 Gasoline	BCMii(Body Control Module)																											
Ford	Ranger	2.5 Gasoline	DDM(Driver's Door Module)																											
Ford	Ranger	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																											
Ford	Ranger	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Ranger	2.5 Gasoline	IPC(Instrument Panel Control Module)																											
Ford	Ranger	2.5 Gasoline	PAM(Parking Aid Module)																											
Ford	Ranger	2.5 Gasoline	PDM(Passenger's Door Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																						V					
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	SRM(Speech Recognition Module)																											
Ford	Ranger	2.5 Gasoline	TBM(Tracking And Blocking Module)							V	V	V																		
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TRM(Trailer Module)																											
Ford	Ranger	2.5 Gasoline	PATS(Passive Anti Theft System)-BETA																											
Ford	Ranger	3.0L	Other	SYSTEM SEARCH																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	GEM(Generic Electronic Module)					V																					
Ford	Ranger	3.0L	Other	IC(Instrument Cluster)																										
Ford	Ranger	3.0L	Other	OCSM(Occupant Classification System Module)																				V						
Ford	Ranger	3.0L	Other	4X4(4x4 Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																						V				
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	SDARS(Satellite Digital Audio Receiver System)																	V									
Ford	Ranger	3.0L	FFV	SYSTEM SEARCH																										
Ford	Ranger	3.0L	FFV	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	FFV	PATS(Passive Anti Theft System)																										
Ford	Ranger	3.0L	FFV	RAP(Remote Anti-Theft/Personality Module)																										
Ford	Ranger	3.0L	FFV	RCM(Restraint Control Module)																				V						
Ford	Ranger	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Ranger	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Ranger	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Ranger	4.0L	V6 (SOHC)	IC(Instrument Cluster)					V																					
Ford	Ranger	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	4X4(4x4 Control Module)																				V						
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																						V				
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																	V									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																						V	V		
Ford	Taurus	3.5L	4V	2008 ~ 2009	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ACM(Audio Control Module)										V	V	V	V	V											
Ford	Taurus	3.5L	4V	2008 ~ 2009	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Taurus	3.5L	4V	2008 ~ 2009	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																	V								
Ford	Taurus	3.5L	4V	2008 ~ 2009	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	IC(Instrument Cluster)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	LTM(Liftgate/Trunk Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	OCSM(Occupant Classification System Module)																			V						
Ford	Taurus	3.5L	4V	2008 ~ 2009	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SDARS(Satellite Digital Audio Receiver System)																V									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SECM(Steering Effort Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)										V															
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Taurus	3.5L	4V	2010 ~ 2012	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FDIM(Front Display Interface Module)											V														
Ford	Taurus	3.5L	4V	2010 ~ 2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																	V								
Ford	Taurus	3.5L	4V	2010 ~ 2012	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HUD(Head Up Display)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																		V	V						
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																		V							
Ford	Taurus	3.5L	4V	2010 ~ 2012	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RCM(Restraint Control Module)																				V					
Ford	Taurus	3.5L	4V	2010 ~ 2012	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PCM(PowerTrain Control Module)																					V	V			
Ford	Taurus	3.5L	TiVCT	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)										V															
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)										V	V		V												
Ford	Taurus	3.5L	TiVCT	2013 ~	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Taurus	3.5L	TiVCT	2013 ~	BCM(Body Control Module)																	V								V
Ford	Taurus	3.5L	TiVCT	2013 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Taurus	3.5L	TiVCT	2013 ~	GFM(Generic Function Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																		V	V						
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																		V							
Ford	Taurus	3.5L	TiVCT	2013 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RACM(Rear Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RCM(Restraint Control Module)																				V					
Ford	Taurus	3.5L	TiVCT	2013 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SCCM(Steering Column Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																					V	V		
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																					V	V		
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ACM(Audio Control Module)										V															
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	APIM(Accessory Protocol Interface Module)															V	V									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																V									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																			V	V					
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																			V						
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RCM(Restraint Control Module)																					V				
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.0L	2000 ~	SYSTEM SEARCH																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	2000 ~	EATC(Electronic Automatic Temperature Control)																										
Ford	Taurus	3.0L	2000 ~	GEM(Generic Electronic Module)																		V								
Ford	Taurus	3.0L	2000 ~	IC(Instrument Cluster)																										
Ford	Taurus	3.0L	2000 ~	RCM(Restraint Control Module)																				V						
Ford	Taurus	3.0L	~ 1999	SYSTEM SEARCH																										
Ford	Taurus	3.0L	~ 1999	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	~ 1999	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	~ 1999	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	RIM(Remote Immobilizer Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																							V	V		
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)											V															
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																V	V									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																		V								V
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																					V					
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SYSTEM SEARCH																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PCM(PowerTrain Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ABS(Anti-Lock Brake System)				V																						
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ACM(Audio Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	GEM(Generic Electronic Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	IC(Instrument Cluster)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PAM(Parking Aid Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	RCM(Restraint Control Module)																					V					
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SRM(Speech Recognition Module)																										
Ford	Transit	2.0L	2001 ~ 2004	SYSTEM SEARCH																										
Ford	Transit	2.0L	2001 ~ 2004	PCM(PowerTrain Control Module)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.0L	2001 ~ 2004	ASM(Auto Shift Manual)																										
Ford	Transit	2.0L	2001 ~ 2004	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.0L	2001 ~ 2004	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	CSM(Central Security Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2006.5	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2006.5	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	2.4L DIESEL	2006.5	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	PAM(Parking Aid Module)																										
Ford	Transit	2.4L DIESEL	2006.5	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	TBM(Tracking And Blocking Module)																										
Ford	Transit	2.5L DIESEL	SYSTEM SEARCH																											
Ford	Transit	2.5L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	ASM(Auto Shift Manual)																											
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																										
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Transit	2.5L DIESEL	RCM(Restraint Control Module)																											
Ford	Transit	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Transit	2.5L DIESEL	CSM(Central Security Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	RIM(Remote Immobilizer Module)																											
Ford	Transit	2.5L DIESEL	ACM(Audio Control Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																							V			
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																						V				
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Transit	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Transit	3.7L	TiVCT	PCM(PowerTrain Control Module)																							V			
Ford	Transit	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Transit	3.7L	TiVCT	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.7L	TiVCT	BCM(Body Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Ford	Transit	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Transit	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.7L	TiVCT	IPM-A(Image Processing Module A)																										
Ford	Transit	3.7L	TiVCT	IPM-B(Image Processing Module B)																										
Ford	Transit	3.7L	TiVCT	PAM(Park Aid Module)																										
Ford	Transit	3.7L	TiVCT	RCM(Restraint Control Module)																						V				
Ford	Transit	3.7L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.7L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.7L	TiVCT	TRM(Trailer Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)				V																						
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																						V				
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Thunderbird	3.9L	4V	SYSTEM SEARCH																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ACM(Audio Control Module)																										
Ford	Thunderbird	3.9L	4V	DDM(Driver's Door Module)																										
Ford	Thunderbird	3.9L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Thunderbird	3.9L	4V	GEM(Generic Electronic Module)																										
Ford	Thunderbird	3.9L	4V	HEC(Hybrid Electrical Cluster)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	REM(Rear Electronic Module)																										
Lincoln	Aviator	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Aviator	4.6L	4V	PCM(Powertrain Control Module)																										
Lincoln	Aviator	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Aviator	4.6L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Aviator	4.6L	4V	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	Aviator	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Aviator	4.6L	4V	IC(Instrument Cluster)																										
Lincoln	Aviator	4.6L	4V	PAM(Parking Aid Module)																										
Lincoln	Aviator	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Aviator	4.6L	4V	TPM(Tire Pressure Monitor)																										
Lincoln	Aviator	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Lincoln	Aviator	4.6L	4V	VSM(Vehicle Security Module)																										
Lincoln	Continental	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Continental	4.6L	4V	PCM(PowerTrain Control Module)																										
Lincoln	Continental	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Continental	4.6L	4V	ACM(Audio Control Module)																										
Lincoln	Continental	4.6L	4V	CPM(Cellular Phone Module)																										
Lincoln	Continental	4.6L	4V	DDM(Driver's Door Module)																										
Lincoln	Continental	4.6L	4V	DSM(Driver's Seat Module)																										
Lincoln	Continental	4.6L	4V	LCM(Lighting Control Module)																										
Lincoln	Continental	4.6L	4V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Continental	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Continental	4.6L	4V	VDM(Vehicle Dynamic Module)																										
Lincoln	Continental	4.6L	4V	VIC(Virtual Image Cluster)																										
Lincoln	Continental	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Continental	4.6L	4V	PATS(Passive Anti Theft System)																										
Lincoln	LS	ALL	SYSTEM SEARCH																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	ABS(Anti-Lock Brake System)																											
Lincoln	LS	ALL	DCSM(Driver-Dual Climate Control Seat Module)																											
Lincoln	LS	ALL	DDM(Driver's Door Module)																											
Lincoln	LS	ALL	DSM(Driver's Seat Module)																											
Lincoln	LS	ALL	EPB(Electronic Parking Brake)																											
Lincoln	LS	ALL	PAM(Parking Aid Module)																											
Lincoln	LS	ALL	RCM(Restraint Control Module)																					V						
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	SCLM(Steering Column Locking Module)																											
Lincoln	LS	ALL	EATC(Electronic Automatic Temperature Control)																											
Lincoln	LS	ALL	GEM(Generic Electronic Module)																											
Lincoln	LS	ALL	HEC(Hybrid Electrical Cluster)																											
Lincoln	LS	ALL	PCSM(Passenger Climate Control Seat Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	MKS	3.7L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2009	PCM(Powertrain Control Module)								V																	
Lincoln	MKS	3.7L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2009	ACM(Audio Control Module)										V															
Lincoln	MKS	3.7L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																V									
Lincoln	MKS	3.7L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2009	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2009	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2009	OCSM(Occupant Classification System Module)																			V						
Lincoln	MKS	3.7L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2009	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2010 ~	PCM(PowerTrain Control Module)								V																	
Lincoln	MKS	3.7L	4V	2010 ~	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2010 ~	ACM(Audio Control Module)										V															
Lincoln	MKS	3.7L	4V	2010 ~	APIM(Accessory Protocol Interface Module)															V	V									
Lincoln	MKS	3.7L	4V	2010 ~	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																V									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	MKS	3.7L	4V	2010 ~	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2010 ~	HUD(Head Up Display)																									
Lincoln	MKS	3.7L	4V	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2010 ~	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	OCSM(Occupant Classification System Module)																		V	V						
Lincoln	MKS	3.7L	4V	2010 ~	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RCM(Restraint Control Module)																				V					
Lincoln	MKS	3.7L	4V	2010 ~	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																					V	V			
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																					V	V			
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM(Audio Control Module)										V															
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	APIM(Accessory Protocol Interface Module)															V	V									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																V									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)			V															V	V						
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)			V															V							
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM(Restraint Control Module)																				V					
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																					V	V			
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																					V	V			
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM(Audio Control Module)										V															
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM(Accessory Protocol Interface Module)															V	V									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GEM/SJB(Generic Electronic Module/Smart Junction Box)																V									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																		V	V						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																			V						
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM(Restraint Control Module)																					V				
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																						V	V		
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																						V	V		
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ACM(Audio Control Module)										V															
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	APIM(Accessory Protocol Interface Module)															V	V									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																V									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																			V	V					
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																			V						
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RCM(Restraint Control Module)																					V				
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKX	3.5L	4V	2007	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																						V	V		
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)								V																	
Lincoln	MKX	3.5L	4V	2007	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2007	ABS(Anti-Lock Brake System)									V																
Lincoln	MKX	3.5L	4V	2007	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2007	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2007	EATC(Electronic Automatic Temperature Control)																									
Lincoln	MKX	3.5L	4V	2007	GEM(Generic Electronic Module)																									
Lincoln	MKX	3.5L	4V	2007	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2007	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2007	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2007	OCSM(Occupant Classification System Module)																			V						
Lincoln	MKX	3.5L	4V	2007	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2007	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2007	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2007	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2007	SDARS(Satellite Digital Audio Receiver System)															V										
Lincoln	MKX	3.5L	4V	2008	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																						V	V		
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)								V																	
Lincoln	MKX	3.5L	4V	2008	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2008	ABS(Anti-Lock Brake System)									V																
Lincoln	MKX	3.5L	4V	2008	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2008	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2008	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																V									
Lincoln	MKX	3.5L	4V	2008	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	MKX	3.5L	4V	2008	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2008	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2008	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2008	OCSM(Occupant Classification System Module)																			V						
Lincoln	MKX	3.5L	4V	2008	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2008	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2008	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2008	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2008	SDARS(Satellite Digital Audio Receiver System)																V									
Lincoln	MKX	3.5L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																					V	V			
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)								V																	
Lincoln	MKX	3.5L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2009	ABS(Anti-Lock Brake System)									V																
Lincoln	MKX	3.5L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																	V								
Lincoln	MKX	3.5L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2009	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2009	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2009	OCSM(Occupant Classification System Module)																			V						
Lincoln	MKX	3.5L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2009	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2009	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2009	SDARS(Satellite Digital Audio Receiver System)																V									
Lincoln	MKX	3.5L	4V	2010	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																					V	V			
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)								V																	
Lincoln	MKX	3.5L	4V	2010	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2010	ABS(Anti-Lock Brake System)									V																
Lincoln	MKX	3.5L	4V	2010	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2010	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	MKX	3.5L	4V	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																	V								
Lincoln	MKX	3.5L	4V	2010	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2010	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2010	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2010	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2010	OCSM(Occupant Classification System Module)																			V						
Lincoln	MKX	3.5L	4V	2010	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2010	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2010	SDARS(Satellite Digital Audio Receiver System)																V									
Lincoln	MKZ	3.0L	2006	SYSTEM SEARCH																										
Lincoln	MKZ	3.0L	2006	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.0L	2006	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.0L	2006	ACM(Audio Control Module)																										
Lincoln	MKZ	3.0L	2006	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.0L	2006	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.0L	2006	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.0L	2006	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.0L	2006	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.0L	2006	GEM(Generic Electronic Module)				V																						
Lincoln	MKZ	3.0L	2006	IC(Instrument Cluster)																										
Lincoln	MKZ	3.0L	2006	OCSM(Occupant Classification System Module)																				V						
Lincoln	MKZ	3.0L	2006	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.0L	2006	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2007	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2007	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2007	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2007	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2007	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2007	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2007	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	MKZ	3.5L	2007	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2007	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.5L	2007	GEM(Generic Electronic Module)					V																					
Lincoln	MKZ	3.5L	2007	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2007	OCSM(Occupant Classification System Module)																				V						
Lincoln	MKZ	3.5L	2007	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2007	SDARS(Satellite Digital Audio Receiver System)																	V									
Lincoln	MKZ	3.5L	2007	PATS(Passive Anti Theft System)																										
Lincoln	MKZ	3.5L	2008	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2008	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2008	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2008	ABS(Anti-Lock Brake System)										V																
Lincoln	MKZ	3.5L	2008	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2008	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2008	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2008	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2008	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Lincoln	MKZ	3.5L	2008	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2008	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2008	OCSM(Occupant Classification System Module)																				V	V					
Lincoln	MKZ	3.5L	2008	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2008	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2008	SDARS(Satellite Digital Audio Receiver System)																	V									
Lincoln	MKZ	3.5L	2008	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2009	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2009	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2009	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2009	ABS(Anti-Lock Brake System)										V																
Lincoln	MKZ	3.5L	2009	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2009	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2009	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2009	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2009	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	MKZ	3.5L	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Lincoln	MKZ	3.5L	2009	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2009	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2009	OCSM(Occupant Classification System Module)																				V	V					
Lincoln	MKZ	3.5L	2009	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2009	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2009	SDARS(Satellite Digital Audio Receiver System)																	V									
Lincoln	MKZ	3.5L	2009	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2010	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2010	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2010	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2010	ABS(Anti-Lock Brake System)										V																
Lincoln	MKZ	3.5L	2010	ACM(Audio Control Module)											V	V		V												
Lincoln	MKZ	3.5L	2010	APIM(Accessory Protocol Interface Module)																V	V									
Lincoln	MKZ	3.5L	2010	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2010	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2010	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	3.5L	2010	FDIM(Front Display Interface Module)																										
Lincoln	MKZ	3.5L	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Lincoln	MKZ	3.5L	2010	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	3.5L	2010	HCM(Headlamp Control Module)																										
Lincoln	MKZ	3.5L	2010	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2010	ILCM(Interior Lighting Control Module)																										
Lincoln	MKZ	3.5L	2010	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	3.5L	2010	OCSM(Occupant Classification System Module)																				V	V					
Lincoln	MKZ	3.5L	2010	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2010	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2010	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	3.5L	2010	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	3.5L	2010	TCM(Transmission Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																								V		
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																V	V									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										V
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRCM(Transmission Range Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																								V		
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																V	V									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM(Body Control Module)																										V
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM(Transmission Range Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Lincoln	Navigator	2007 ~	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																							V	V		
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)										V																
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)											V	V	V	V	V											
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)											V	V		V												
Lincoln	Navigator	2007 ~	5.4L	APIM(Accessory Protocol Interface Module)																V	V									
Lincoln	Navigator	2007 ~	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GPSM(Global Positioning System Module)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	IC(Instrument Cluster)																			V							
Lincoln	Navigator	2007 ~	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	2007 ~	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	2007 ~	5.4L	PRB(Power Running Board)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																						V				
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																						V				
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCU(Audio Rear Control Unit)																										
Lincoln	Navigator	2007 ~	5.4L	RETM(Rear Entertainment Module)																										
Lincoln	Navigator	2007 ~	5.4L	SDARS(Satellite Digital Audio Receiver System)																	V									
Lincoln	Navigator	2007 ~	5.4L	TCCM(Transfer Case Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	TCM(Transmission Control Module)									V																	
Lincoln	Navigator	2007 ~	5.4L	VDM(Vehicle Dynamic Module)		V																								
Lincoln	Navigator	2007 ~	5.4L	4X4(4x4 Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PATS(Passive Anti Theft System)																										
Lincoln	Navigator	~ 2007	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)									V																	

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)										V																
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	GEM(Generic Electronic Module)																										
Lincoln	Navigator	~ 2007	5.4L	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Navigator	~ 2007	5.4L	IC(Instrument Cluster)																			V							
Lincoln	Navigator	~ 2007	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	~ 2007	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																						V				
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																				V						
Lincoln	Navigator	~ 2007	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	~ 2007	5.4L	RIM(Remote Immobilizer Module)																										
Lincoln	Navigator	~ 2007	5.4L	VSM(Vehicle Security Module)																		V								
Lincoln	Town Car	4.6L	2V	SYSTEM SEARCH																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)									V																	
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	LCM(Lighting Control Module)																										
Lincoln	Town Car	4.6L	2V	VDM(Vehicle Dynamic Module)		V																								
Lincoln	Town Car	4.6L	2V	DDM(Driver's Door Module)																										
Lincoln	Town Car	4.6L	2V	DSM(Driver's Seat Module)																										
Lincoln	Town Car	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Town Car	4.6L	2V	RATC(Rear Air Temperature Control)																										
Lincoln	Town Car	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Lincoln	Town Car	4.6L	2V	PAM(Parking Aid Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	HEC(Hybrid Electrical Cluster)																										
Lincoln	Town Car	4.6L	2V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Town Car	4.6L	2V	RASM(Rear Air Suspension Module)																										
Mercury	Grand Marquis	4.6L	2V	SYSTEM SEARCH																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	DDM(Driver's Door Module)																										
Mercury	Grand Marquis	4.6L	2V	IC(Instrument Cluster)																										
Mercury	Grand Marquis	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Grand Marquis	4.6L	2V	LCM(Lighting Control Module)																										
Mercury	Grand Marquis	4.6L	2V	MC(Message Center)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RIM(Remote Immobilizer Module)																										
Mercury	Grand Marquis	4.6L	2V	GEM(Generic Electronic Module)																										
Mercury	Grand Marquis	4.6L	2V	VDM(Vehicle Dynamic Module)		V																								
Mercury	Marauder	4.6L	4V	SYSTEM SEARCH																										
Mercury	Marauder	4.6L	4V	PCM(Powertrain Control Module)																										
Mercury	Marauder	4.6L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Marauder	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Marauder	4.6L	4V	RASM(Rear Air Suspension Module)																										
Mercury	Marauder	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Mercury	Marauder	4.6L	4V	DDM(Driver's Door Module)																										
Mercury	Marauder	4.6L	4V	LCM(Lighting Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																				V						
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																							V			
Mercury	Milan	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)										V																
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)											V	V		V												
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)											V	V		V												
Mercury	Milan	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																V	V									
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Mercury	Milan	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																				V	V					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	Milan	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																				V	V	V				
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)						V	V	V																		
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																							V	V		
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)											V	V		V												
Mercury	Milan	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																V	V									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																				V	V					
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)						V	V	V																		
Mercury	Milan	3.0L	4V	SYSTEM SEARCH																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																							V			
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Milan	3.0L	4V	ABS(Anti-Lock Brake System)										V																
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)											V	V		V												
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	Milan	3.0L	4V	APIM(Accessory Protocol Interface Module)																V	V									
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Mercury	Milan	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																				V	V					
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																				V						
Mercury	Milan	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Milan	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																				V	V	V				
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																						V				
Mercury	Milan	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	Milan	3.0L	4V	TBM(Tracking And Blocking Module)						V	V	V																		
Mercury	Milan	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																	V									
Mercury	Milan	3.0L	4V	PATS(Passive Anti Theft System)																										
Mercury	Montego	3.0L	4V	SYSTEM SEARCH																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Montego	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Montego	3.0L	4V	ACM(Audio Control Module)											V															
Mercury	Montego	3.0L	4V	DSM(Driver's Seat Module)																										
Mercury	Montego	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Montego	3.0L	4V	GEM(Generic Electronic Module)																										
Mercury	Montego	3.0L	4V	IC(Instrument Cluster)																			V							
Mercury	Montego	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Montego	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Montego	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																					V						
Mercury	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Mercury	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																					V						
Mercury	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Mercury	Mountaineer	2010 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ABS(Anti-Lock Brake System)										V																
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)												V		V												
Mercury	Mountaineer	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																V	V									
Mercury	Mountaineer	2010 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2010 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)					V																					
Mercury	Mountaineer	2010 MY	4.6L	IC(Instrument Cluster)																			V							
Mercury	Mountaineer	2010 MY	4.6L	OCSM(Occupant Classification System Module)																				V						
Mercury	Mountaineer	2010 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.6L	RCM(Restraint Control Module)																						V				
Mercury	Mountaineer	2010 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																	V									
Mercury	Mountaineer	2010 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.0L	PCM(Powertrain Control Module)									V																	
Mercury	Mountaineer	2010 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ABS(Anti-Lock Brake System)										V																
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)												V		V												
Mercury	Mountaineer	2010 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2010 MY	4.0L	GEM(Generic Electronic Module)					V																					
Mercury	Mountaineer	2010 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.0L	OCSM(Occupant Classification System Module)																				V						
Mercury	Mountaineer	2010 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.0L	RCM(Restraint Control Module)																						V				
Mercury	Mountaineer	2010 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																	V									
Mercury	Mountaineer	2009 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.6L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	Mountaineer	2009 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ABS(Anti-Lock Brake System)										V																
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)												V		V												
Mercury	Mountaineer	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																V	V									
Mercury	Mountaineer	2009 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2009 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)					V																					
Mercury	Mountaineer	2009 MY	4.6L	IC(Instrument Cluster)																			V							
Mercury	Mountaineer	2009 MY	4.6L	OCSM(Occupant Classification System Module)																				V						
Mercury	Mountaineer	2009 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.6L	RCM(Restraint Control Module)																						V				
Mercury	Mountaineer	2009 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																	V									
Mercury	Mountaineer	2009 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.0L	PCM(Powertrain Control Module)									V																	
Mercury	Mountaineer	2009 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ABS(Anti-Lock Brake System)										V																
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)												V		V												
Mercury	Mountaineer	2009 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2009 MY	4.0L	GEM(Generic Electronic Module)					V																					
Mercury	Mountaineer	2009 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.0L	OCSM(Occupant Classification System Module)																				V						
Mercury	Mountaineer	2009 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.0L	RCM(Restraint Control Module)																						V				
Mercury	Mountaineer	2009 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																	V									
Mercury	Mountaineer	2008 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ABS(Anti-Lock Brake System)										V																

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)												V		V												
Mercury	Mountaineer	2008 MY	4.6L	APIM(Accessory Protocol Interface Module)																V	V									
Mercury	Mountaineer	2008 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2008 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)					V																					
Mercury	Mountaineer	2008 MY	4.6L	IC(Instrument Cluster)																			V							
Mercury	Mountaineer	2008 MY	4.6L	OCSM(Occupant Classification System Module)																				V						
Mercury	Mountaineer	2008 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.6L	RCM(Restraint Control Module)																						V				
Mercury	Mountaineer	2008 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																	V									
Mercury	Mountaineer	2008 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.0L	PCM(Powertrain Control Module)									V																	
Mercury	Mountaineer	2008 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ABS(Anti-Lock Brake System)										V																
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)												V		V												
Mercury	Mountaineer	2008 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2008 MY	4.0L	GEM(Generic Electronic Module)					V																					
Mercury	Mountaineer	2008 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.0L	OCSM(Occupant Classification System Module)																				V						
Mercury	Mountaineer	2008 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.0L	RCM(Restraint Control Module)																						V				
Mercury	Mountaineer	2008 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																	V									
Mercury	Mountaineer	2007 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ABS(Anti-Lock Brake System)										V																
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)												V		V												
Mercury	Mountaineer	2007 MY	4.6L	APIM(Accessory Protocol Interface Module)																V	V									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	Mountaineer	2007 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2007 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)					V																					
Mercury	Mountaineer	2007 MY	4.6L	IC(Instrument Cluster)																			V							
Mercury	Mountaineer	2007 MY	4.6L	OCSM(Occupant Classification System Module)																				V						
Mercury	Mountaineer	2007 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.6L	RCM(Restraint Control Module)																						V				
Mercury	Mountaineer	2007 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																	V									
Mercury	Mountaineer	2007 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.0L	PCM(Powertrain Control Module)									V																	
Mercury	Mountaineer	2007 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ABS(Anti-Lock Brake System)										V																
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)												V		V												
Mercury	Mountaineer	2007 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2007 MY	4.0L	GEM(Generic Electronic Module)					V																					
Mercury	Mountaineer	2007 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.0L	OCSM(Occupant Classification System Module)																				V						
Mercury	Mountaineer	2007 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.0L	RCM(Restraint Control Module)																						V				
Mercury	Mountaineer	2007 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																	V									
Mercury	Mountaineer	2006 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ABS(Anti-Lock Brake System)										V																
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)												V		V												
Mercury	Mountaineer	2006 MY	4.6L	APIM(Accessory Protocol Interface Module)																V	V									
Mercury	Mountaineer	2006 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2006 MY	4.6L	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	Mountaineer	2006 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)					V																					
Mercury	Mountaineer	2006 MY	4.6L	IC(Instrument Cluster)																			V							
Mercury	Mountaineer	2006 MY	4.6L	OCSM(Occupant Classification System Module)																				V						
Mercury	Mountaineer	2006 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.6L	RCM(Restraint Control Module)																						V				
Mercury	Mountaineer	2006 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																	V									
Mercury	Mountaineer	2006 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.0L	PCM(Powertrain Control Module)									V																	
Mercury	Mountaineer	2006 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ABS(Anti-Lock Brake System)										V																
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)												V		V												
Mercury	Mountaineer	2006 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2006 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2006 MY	4.0L	GEM(Generic Electronic Module)					V																					
Mercury	Mountaineer	2006 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.0L	OCSM(Occupant Classification System Module)																				V						
Mercury	Mountaineer	2006 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.0L	RCM(Restraint Control Module)																						V				
Mercury	Mountaineer	2006 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																	V									
Mercury	Mountaineer	2003 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2003 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2003 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2003 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2003 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2003 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2003 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2002 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2002 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2002 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2002 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	Mountaineer	2002 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2002 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2001 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2001 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2001 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2001 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2001 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2001 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2000 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2000 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2000 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2000 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2000 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2000 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	1999 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1999 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1999 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1999 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1999 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1999 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	1998 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1998 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1998 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1998 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1998 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1997 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1997 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1997 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1997 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1997 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																							V	V		
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									V	
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)											V	V		V												
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																			V	V						
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																						V				
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																							V	V		
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									V	
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)											V	V		V												
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																			V	V						
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																						V				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)										V																
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)											V	V	V	V	V											
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																						V	V			
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)										V																
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)												V		V												
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																V	V									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)												V														
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																				V						
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																						V				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Accurate Trim Test	ABS Service Bleed(ABS)	ABS Service Bleed(ABS/ESP)	Remote Keyless Entry	TBM SIM RAV_ID-Test	Reset TBM Password-Test	TBM Transit Mode-Test	TR Sensor Test	IVD Initialzation Sequence	ACM Module Installation	Infotainment Display Test	Microphone Test	Audio Speaker Walkaround Test	Monotones Test	Rear Tones Test	Tones Test	Remote Keyless Entry Code	IC Module Installation	Passenger System Reset	Passenger Zero Seat Weight Test	RCM Module Installation	Misfire Monitor Neutral Profile Correction	Relearn Vehicle Data	Longitudinal Acceleration Sensor	CEI Lock Configuration
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																							V	V		
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)										V																
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)												V		V												
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																V	V									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)												V														
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																				V						
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																						V				
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Vehicle Info.	Vehicle Info.	Vehicle Info.																												
Ford	Crown Victoria	4.6L	2V	SYSTEM SEARCH																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	DDM(Driver's Door Module)																										
Ford	Crown Victoria	4.6L	2V	IC(Instrument Cluster)																										
Ford	Crown Victoria	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Crown Victoria	4.6L	2V	LCM(Lighting Control Module)																										
Ford	Crown Victoria	4.6L	2V	MC(Message Center)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	Crown Victoria	4.6L	2V	GEM(Generic Electronic Module)																										
Ford	Crown Victoria	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.4L	DIESEL	SYSTEM SEARCH																										
Ford	Ecosport	1.4L	DIESEL	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.4L	DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.4L	DIESEL	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.4L	DIESEL	IC(Instrument Cluster)																										
Ford	Ecosport	1.4L	DIESEL	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	FFV	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Ecosport	1.6L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	FFV	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Escort	2.0L	SYSTEM SEARCH																											
Ford	Escort	2.0L	PCM(PowerTrain Control Module)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ECS(Electronic Crash Sensor)																											
Ford	Escort	2.0L	PATS(Passive Anti Theft System)																											
Ford	Escort	2.0L	RAP(Remote Anti-Theft/Personality Module)																											
Ford	Edge	3.5L	4V	SYSTEM SEARCH																										
Ford	Edge	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Edge	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Edge	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Edge	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	4V	IC(Instrument Cluster)																										
Ford	Edge	3.5L	4V	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Edge	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Edge	3.5L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Edge	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.5L	TiVCT	BCM(Body Control Module)		V																								
Ford	Edge	3.5L	TiVCT	C-CM(Cruise Control Module)			V	V																						
Ford	Edge	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)					V																					
Ford	Edge	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)						V																				
Ford	Edge	3.5L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	TiVCT	RFA(Remote Function Actuator)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Edge	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.5L	TiVCT	SCCM(Steering Column Control Module)							V																			
Ford	Edge	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.5L	TiVCT	PATS(Passive Anti Theft System)								V	V																	
Ford	Edge	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.7L	TiVCT	BCM(Body Control Module)		V																								
Ford	Edge	3.7L	TiVCT	C-CM(Cruise Control Module)			V	V																						
Ford	Edge	3.7L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)					V																					
Ford	Edge	3.7L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.7L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)						V																				
Ford	Edge	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.7L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.7L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Edge	3.7L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.7L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.7L	TiVCT	SCCM(Steering Column Control Module)							V																			
Ford	Edge	3.7L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.7L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.7L	TiVCT	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.7L	TiVCT	PATS(Passive Anti Theft System)								V	V																	
Ford	Escape	Up to 2004	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Escape	Up to 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	Up to 2004	Immobilizer											V	V	V														
Ford	Escape	Up to 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	Up to 2004	RCM(Restraint Control Module)																											
Ford	Escape	Up to 2004	GEM(Generic Electronic Module)																											
Ford	Escape	From 2004	SYSTEM SEARCH																											
Ford	Escape	From 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	From 2004	PATS(Passive Anti Theft System)														V	V												
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	RCM(Restraint Control Module)																											
Ford	Escape	From 2004	IC(Instrument cluster)																											
Ford	Escape	From 2004	GEM(Generic Electronic Module)																											
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)															V	V	V									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																		V								
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																			V	V	V					
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																						V	V			
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)															V	V	V									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																			V	V	V					
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																					V	V				
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																							V			
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																								V	V
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																		V								
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																									V	V
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																		V								
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																									V	V
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Excursion	GASOLINE	SYSTEM SEARCH																											
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											
Ford	Excursion	GASOLINE	ABS(Anti-Lock Brake System)																											
Ford	Excursion	GASOLINE	CSM(Central Security Module)																											
Ford	Excursion	GASOLINE	DSM(Driver's Seat Module)																											
Ford	Excursion	GASOLINE	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	GASOLINE	ECS(Electronic Crash Sensor)																											
Ford	Excursion	GASOLINE	GEM(Generic Electronic Module)																											
Ford	Excursion	GASOLINE	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	GASOLINE	OTC(Overhead Trip Computer)																											
Ford	Excursion	GASOLINE	PAM(Parking Aid Module)																											
Ford	Excursion	GASOLINE	PATS(Passive Anti Theft System)																											
Ford	Excursion	GASOLINE	TCM(Transmission Control Module)																											
Ford	Excursion	GASOLINE	VSM(Vehicle Security Module)																											
Ford	Excursion	DIESEL	SYSTEM SEARCH																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Excursion	DIESEL	CSM(Central Security Module)																											
Ford	Excursion	DIESEL	DSM(Driver's Seat Module)																											
Ford	Excursion	DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	DIESEL	ECS(Electronic Crash Sensor)																											
Ford	Excursion	DIESEL	GEM(Generic Electronic Module)																											
Ford	Excursion	DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	DIESEL	OTC(Overhead Trip Computer)																											
Ford	Excursion	DIESEL	PAM(Parking Aid Module)																											
Ford	Excursion	DIESEL	PATS(Passive Anti Theft System)																											
Ford	Excursion	DIESEL	TCM(Transmission Control Module)																											
Ford	Excursion	DIESEL	VSM(Vehicle Security Module)																											
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	EATC(Electronic Automatic Temperature Control)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VSM(Vehicle Security Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TBC(Trailer Brake Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCCM(Transfer Case Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	GEM(Generic Electronic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	5.4L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VSM(Vehicle Security Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	APIM(Accessory Protocol Interface Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GPSM(Global Positioning System Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	4.6L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PRB(Power Running Board)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCU(Audio Rear Control Unit)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RETM(Rear Entertainment Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	TCM(Transmission Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	4X4(4x4 Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VSM(Vehicle Security Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	BCM(Body Control Module)	V																								
Ford	Explorer	2015 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	C-CM(Cruise Control Module)		V	V																						

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2015 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)					V																				
Ford	Explorer	2015 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)						V																			
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)	V																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)		V	V																						
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)						V																			
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	BCM(Body Control Module)	V																								
Ford	Explorer	2014 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	C-CM(Cruise Control Module)		V	V																						
Ford	Explorer	2014 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)					V																				

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2014 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)						V																			
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)	V																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)		V	V																						
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)						V																			
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	BCM(Body Control Module)	V																								
Ford	Explorer	2013 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	C-CM(Cruise Control Module)		V	V																						
Ford	Explorer	2013 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)					V																				
Ford	Explorer	2013 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)						V																			
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PATS(Passive Anti Theft System)							V	V																	
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)	V																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)		V	V																						
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)						V																			
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2012 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	BCM(Body Control Module)	V																								
Ford	Explorer	2012 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	C-CM(Cruise Control Module)		V	V																						
Ford	Explorer	2012 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)					V																				
Ford	Explorer	2012 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)						V																			
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)	V																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)		V	V																						
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)						V																			
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	BCM(Body Control Module)	V																								
Ford	Explorer	2011 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	C-CM(Cruise Control Module)		V	V																						
Ford	Explorer	2011 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)					V																				
Ford	Explorer	2011 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)						V																			
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)	V																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)		V	V																						
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)						V																			
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2010 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2009 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2005 MY	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2005 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2005 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2005 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2005 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2005 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2004 MY	SYSTEM SEARCH																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2004 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2004 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2004 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2004 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2004 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2003 MY	SYSTEM SEARCH																											
Ford	Explorer	2003 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2003 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2003 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2003 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2003 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2003 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2003 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2002 MY	SYSTEM SEARCH																											
Ford	Explorer	2002 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2002 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2002 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2002 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2002 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2002 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2002 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2001 MY	SYSTEM SEARCH																											
Ford	Explorer	2001 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2001 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2001 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2001 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer	2001 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2001 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	SYSTEM SEARCH																											
Ford	Explorer	2000 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2000 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2000 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	2000 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2000 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	1999 MY	SYSTEM SEARCH																											
Ford	Explorer	1999 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1999 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1999 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1999 MY	PAM(Parking Aid Module)																											
Ford	Explorer	1998 MY	SYSTEM SEARCH																											
Ford	Explorer	1998 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1998 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1998 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1998 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1997 MY	SYSTEM SEARCH																											
Ford	Explorer	1997 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1997 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1997 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1997 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer SportTrac	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer SportTrac	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer SportTrac	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2004 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	RAP(Remote Anti-Theft/Personality Module)																									
Ford	E-Series	5.4L	2V	2004 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2004 ~	VSM(Vehicle Security Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2009 ~	ACM(Audio Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	E-Series	5.4L	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	E-Series	5.4L	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	E-Series	5.4L	2V	2009 ~	IPC(Instrument Panel Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)		V																								
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																						V				
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																							V			
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																										
Ford	F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)		V																								
Ford	F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																						V				
Ford	F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																							V			
Ford	F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																										
Ford	F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																						V			
Ford	F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)					V																				
Ford	F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																									
Ford	F150	4.6L(BETA)	3V	SYSTEM SEARCH																										
Ford	F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																										
Ford	F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																										
Ford	F150	4.6L(BETA)	3V	ACM(Audio Control Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																										
Ford	F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																							V			
Ford	F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																										
Ford	F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)					V																					
Ford	F150	4.6L(BETA)	3V	IC(Instrument Cluster)																										
Ford	F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																										
Ford	F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																										
Ford	F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																										
Ford	F150	4.6L(BETA)	3V	PRB(Power Running Board)																										
Ford	F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																										
Ford	F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																										
Ford	F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																										
Ford	F150	5.0L	TiVCT	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	F150	5.0L	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	5.0L	TiVCT	ACM(Audio Control Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	5.0L	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																		V								
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																							V			
Ford	F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	5.0L	TiVCT	IC(Instrument Cluster)																										
Ford	F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PRB(Power Running Board)																										
Ford	F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																					V					
Ford	F150	5.0L	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	5.0L	TiVCT	TCM(Transmission Control Module)																										
Ford	F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	F150	5.4L	3V	2009 ~	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																						V			
Ford	F150	5.4L	3V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)					V																				
Ford	F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2009 ~	PRB(Power Running Board)																									
Ford	F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	6.2L(BETA)	2V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																										
Ford	F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																										
Ford	F150	6.2L(BETA)	2V	ACM(Audio Control Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																										
Ford	F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																										
Ford	F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																										
Ford	F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																							V			
Ford	F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																										
Ford	F150	6.2L(BETA)	2V	IC(Instrument Cluster)																										
Ford	F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																										
Ford	F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																										
Ford	F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																										
Ford	F150	6.2L(BETA)	2V	PRB(Power Running Board)																										
Ford	F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																										
Ford	F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																										
Ford	F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																										
Ford	F150	Other	2004 ~ 2008	SYSTEM SEARCH																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																										
Ford	F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																										
Ford	F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																										
Ford	F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	Other	2004 ~ 2008	IC(Instrument Cluster)																										
Ford	F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										
Ford	F250	7.3L	SYSTEM SEARCH																											
Ford	F250	7.3L	PCM(PowerTrain Control Module)																											
Ford	F250	7.3L	ABS(Anti-Lock Brake System)																											
Ford	F250	7.3L	ECS(Electronic Crash Sensor)																											
Ford	F250	7.3L	GEM(Generic Electronic Module)																											
Ford	F250	6.2L	SYSTEM SEARCH																											
Ford	F250	6.2L	PCM(Powertrain Control Module)																											
Ford	F250	6.2L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.2L	ACM(Audio Control Module)																											
Ford	F250	6.2L	APIM(Accessory Protocol Control Module)																											
Ford	F250	6.2L	BCMii(Body Control Module)																											
Ford	F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																											
Ford	F250	6.2L	DSM(Driver Seat Module)																											
Ford	F250	6.2L	GPSM(Global Positioning System Module)																											
Ford	F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F250	6.2L	IPC(Instrument Panel Control Module)																											
Ford	F250	6.2L	PAM(Parking Aid Module)																											
Ford	F250	6.2L	RCM(Restraint Control Module)																											
Ford	F250	6.2L	SCCM(Streering Colume Control Module)																											
Ford	F250	6.2L	TBC(Trailer Brake Control Module)																											
Ford	F250	6.2L	TCCM(Transfer Case Control Module)																											
Ford	F250	6.2L	TPM(Tire Pressure Monitor)																											
Ford	F250	6.0L	SYSTEM SEARCH																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.0L	GEM(Generic Electronic Module)																											
Ford	F250	6.0L	HEC(Hybrid Electrical Cluster)																											
Ford	F250	6.0L	OTC(Overhead Trip Computer)																											
Ford	F250	6.0L	PAM(Parking Aid Module)																											
Ford	F250	6.0L	PATS(Passive Anti Theft System)																											
Ford	F250	6.0L	RCM(Restraint Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	VSM(Vehicle Security Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SYSTEM SEARCH																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM(PowerTrain Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4(4x4 Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS(Anti-Lock Brake System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM(Audio Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM(Auxiliary Heater Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM(Accessory Protocol Interface Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM(Circuit Deactivation Ignition Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM(Driver's Seat Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GPSM(Global Positioning System Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC(Instrument Cluster)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM(Parking Aid Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM(Restraint Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM(Rear Entertainment Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS(Satellite Digital Audio Receiver System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC(Trailer Brake Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM(Transmission Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																									
Ford	Fiesta	1.4L	DURATEC 16V	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Fiesta	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	BCMii(Body Control Module)																										
Ford	Fiesta	1.6L	DURATEC	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	BCM(Body Control Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Fiesta	1.6L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	PSCM(Power Steering Control Module)																						V				
Ford	Fiesta	1.6L	TiVCT	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.6L	TiVCT	VSM(Vehicle Security Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	Zetec Rocam	IC(Instrument Cluster)																										
Ford	Fiesta	1.6L	Zetec Rocam	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	RKE(Remote Keyless Entry)																										
Ford	Fiesta	1.6L	Zetec Rocam	TCM(Transmission Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	SYSTEM SEARCH																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																										
Ford	Fiesta	2.0L	SYSTEM SEARCH																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	2.0L	ACM(Audio Control Module)																											
Ford	Fiesta	2.0L	EATC(Electronic Automatic Temperature Control)																											
Ford	Fiesta	2.0L	GEM(Generic Electronic Module)																											
Ford	Fiesta	2.0L	IC(Instrument Cluster)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	RCM(Restraint Control Module)																											
Ford	Fiesta	2.0L	PATS(Passive Anti Theft System)-BETA																											
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)								V																		
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Focus	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	ZETEC ROCAM	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Focus	1.6L	ZETEC ROCAM	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																									V	
Ford	Focus	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Focus	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic power steering)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ACM(Audio control module)																										
Ford	Focus	1.8L	DURATEC HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.8L	DURATEC HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.8L	DURATEC HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.8L	DURATEC HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.8L	DURATEC HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	IC(Instrument cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	NAV(Navigation System)																										
Ford	Focus	1.8L	DURATEC HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	MC(Message Center)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FCIM(Front Controls Interface Module)																		V								
Ford	Focus	2.0L DURATEC HE/I4	2008~	FDIM(Front Display Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TCM(Transmission control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CSM(Central Security Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EPS(Electronic power steering)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GDM(Generic Display Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	NAV(Navigation System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RKE(Remote Keyless Entry)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TBM(Tracking And Blocking Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SRM(Speech recognition module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SYSTEM SEARCH																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ABS(Anti-Lock Brake System)															V	V	V									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ACM(Audio Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	BCM(Body Control Module)																			V	V	V					
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DDM(Driver's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																		V								
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	IPC(Instrument Panel Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PAM(Parking Aid Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PSCM(Power Steering Control Module)																						V	V			
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SASM(Steering Angle Sensor Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Focus	2.0L DIESEL	2003 ~ 2008	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FACM(Fuel Additive Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RETM(Rear Entertainment Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RKE(Remote Keyless Entry)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	TCM(Transmission control module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	DDM(Driver's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	MC(Message Center)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ACM(Audio control module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									V	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																									V	
Ford	Focus C-MAX	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Focus C-MAX	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Flex	3.5L	4V	SYSTEM SEARCH																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	4V	ACM(Audio control module)																										
Ford	Flex	3.5L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	4V	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	4V	FDIM(Front Display Interface Module)																							V			
Ford	Flex	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	4V	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	4V	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	4V	IC(Instrument cluster)																										
Ford	Flex	3.5L	4V	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	4V	LTM(Liftgate/Trunk Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Flex	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	4V	Factory Keyless Entry Code																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio control module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																							V			
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC(Instrument cluster)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Flex	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	TiVCT	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Flex	3.5L	TiVCT	ACM(Audio control module)																										
Ford	Flex	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	TiVCT	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	TiVCT	FDIM(Front Display Interface Module)																							V			
Ford	Flex	3.5L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	TiVCT	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	TiVCT	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	TiVCT	IC(Instrument cluster)																										
Ford	Flex	3.5L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	TiVCT	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Ford	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Ford	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Ford	Freestyle	3.0L	4V	SYSTEM SEARCH																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Freestyle	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Freestyle	3.0L	4V	ACM(Audio Control Module)																										
Ford	Freestyle	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Freestyle	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Freestyle	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Freestyle	3.0L	4V	IC(Instrument Cluster)																										
Ford	Freestyle	3.0L	4V	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Freestyle	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Freestyle	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Five Hundred	3.0L	4V	SYSTEM SEARCH																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Five Hundred	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Five Hundred	3.0L	4V	ACM(Audio Control Module)																										
Ford	Five Hundred	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Five Hundred	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Five Hundred	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Five Hundred	3.0L	4V	IC(Instrument Cluster)																										
Ford	Five Hundred	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Five Hundred	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Five Hundred	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Ford GT	5.4L	4V	SYSTEM SEARCH																										
Ford	Ford GT	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	IC(Instrument Cluster)																										
Ford	Ford GT	5.4L	4V	PATS(Passive Anti Theft System)																										
Ford	Ford GT	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	TCM(Transmission control module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Fusion	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	DURATEC	IC(Instrument cluster)																										
Ford	Fusion	1.6L	DURATEC	ACM(Audio control module)																										
Ford	Fusion	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fusion	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																			V		V					
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)							V																			
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																			V		V					
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)							V																			
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SYSTEM SEARCH																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BCM(Body Control Module)																		V		V						
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HUD(Head Up Display)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCCM(Steering Column Control Module)							V																			
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM(Secondary OBD Control Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	TCU(Telematic Control Unit Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Fusion	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																		V								
Ford	Fusion	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																							V			
Ford	Fusion	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.5L	IVCT	SYSTEM SEARCH																										
Ford	Fusion	2.5L	IVCT	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	IVCT	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	IVCT	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	IVCT	BCM(Body Control Module)																			V							
Ford	Fusion	2.5L	IVCT	C-CM(Cruise Control Module)																										
Ford	Fusion	2.5L	IVCT	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.5L	IVCT	DDM(Driver's Door Module)																										
Ford	Fusion	2.5L	IVCT	DSM(Driver's Seat Module)																										
Ford	Fusion	2.5L	IVCT	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	IVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.5L	IVCT	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	IVCT	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	IVCT	GWM(Gateway Module A)																										
Ford	Fusion	2.5L	IVCT	HUD(Head Up Display)																										
Ford	Fusion	2.5L	IVCT	IPC(Instrument Panel Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Fusion	2.5L	IVCT	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.5L	IVCT	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	IVCT	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	IVCT	PDM(Passenger's Door Module)																										
Ford	Fusion	2.5L	IVCT	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	IVCT	RACM(Rear Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	IVCT	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.5L	IVCT	SCCM(Steering Column Control Module)							V																			
Ford	Fusion	2.5L	IVCT	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.5L	IVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	IVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																							V			
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																		V								
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FDIM(Front Display Interface Module)																							V			
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.0L	4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Fusion	3.5L	4V	SYSTEM SEARCH																										
Ford	Fusion	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.5L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.5L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																		V								
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FDIM(Front Display Interface Module)																							V			
Ford	Fusion	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.5L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.5L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.5L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	KA	2000 MY	SYSTEM SEARCH																											
Ford	KA	2000 MY	PCM(PowerTrain Control Module)																											
Ford	KA	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	KA	2000 MY	RCM(Restraint Control Module)																											
Ford	KA	1999 MY	PCM(PowerTrain Control Module)																											
Ford	KA	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)															V	V	V									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																			V	V	V					
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																						V	V			
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)															V	V	V									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																			V	V	V					
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																						V	V			
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Kuga	2.0L DIESEL	SYSTEM SEARCH																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Kuga	2.0L DIESEL	TCM(Transmission Control Module)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																											
Ford	Kuga	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																											
Ford	Kuga	2.0L DIESEL	AWD(All Wheel Drive Module)																											
Ford	Kuga	2.0L DIESEL	BCMii(Body Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Kuga	2.0L DIESEL	CCMii(Cruise Control Module)																											
Ford	Kuga	2.0L DIESEL	CMR(Camera Module Rear)																											
Ford	Kuga	2.0L DIESEL	D_DCU(Driver Door Control Unit)																											
Ford	Kuga	2.0L DIESEL	DDM(Driver's Door Module)																											
Ford	Kuga	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Kuga	2.0L DIESEL	EPS(Electronic Power Steering)																											
Ford	Kuga	2.0L DIESEL	FDSM(Front Distance Sensing Module)																											
Ford	Kuga	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																											
Ford	Kuga	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Kuga	2.0L DIESEL	GEM(Generic Electronic Module)																											
Ford	Kuga	2.0L DIESEL	GPSM(Global Positioning System Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Kuga	2.0L DIESEL	IPM-A(Image Processing Module A)																											
Ford	Kuga	2.0L DIESEL	IPM-B(Image Processing Module B)																											
Ford	Kuga	2.0L DIESEL	IPC(Instrument Panel Control Module)																											
Ford	Kuga	2.0L DIESEL	IC(Instrument Cluster)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PSCM(Power Steering Control Module)																							V	V			
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RFA(Remote Function Actuator)																											
Ford	Kuga	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																											
Ford	Kuga	2.0L DIESEL	RETM(Rear Entertainment Module)																											
Ford	Kuga	2.0L DIESEL	SASM(Steering Angle Sensor Module)																											
Ford	Kuga	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Kuga	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Kuga	2.0L DIESEL	SRM(Speech Recognition Module)																											
Ford	Kuga	2.0L DIESEL	TRM(Trailer Module)																											
Ford	Kuga	2.5L	I5	SYSTEM SEARCH																										
Ford	Kuga	2.5L	I5	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.5L	I5	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.5L	I5	ACM(Audio Control Module)																										
Ford	Kuga	2.5L	I5	AWD(All Wheel Drive Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Kuga	2.5L	I5	CMR(Camera Module Rear)																										
Ford	Kuga	2.5L	I5	D_DCU(Driver Door Control Unit)																										
Ford	Kuga	2.5L	I5	EATC(Electronic Automatic Temperature Control)																										
Ford	Kuga	2.5L	I5	EPS(Electronic Power Steering)																										
Ford	Kuga	2.5L	I5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Kuga	2.5L	I5	GEM(Generic Electronic Module)																										
Ford	Kuga	2.5L	I5	HCM(Headlamp Control Module)																										
Ford	Kuga	2.5L	I5	IC(Instrument Cluster)																										
Ford	Kuga	2.5L	I5	PAM(Parking Aid Module)																										
Ford	Kuga	2.5L	I5	PDM(Passenger's Door Module)																										
Ford	Kuga	2.5L	I5	RCM(Restraint Control Module)																										
Ford	Kuga	2.5L	I5	RETM(Rear Entertainment Module)																										
Ford	Kuga	2.5L	I5	RKE(Remote Keyless Entry)																										
Ford	Kuga	2.5L	I5	SRM(Speech Recognition Module)																										
Ford	Kuga	2.5L	I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									V	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Mondeo	2010 MY	2.5L I5	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.5L I5	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.5L I5	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.5L I5	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.5L I5	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.5L I5	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.5L I5	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.5L I5	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SYSTEM SEARCH																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																									V	
Ford	Mondeo	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									V	
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	AHCM(Auxiliary Heater Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	BCMii(Body Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CCMii(Cruise Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DDM(Driver's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DSM(Driver's Seat Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HCM(HeadLamp Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RFA(Remote Function Actuator)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TRM(Trailer Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ACM(Audio Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	CDP(Compact Disc Player)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GDM(Generic Display Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	NAV(Navigation System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SRM(Speech Recognition Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	SYSTEM SEARCH																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	GEM(Generic Electronic Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	HCM(Headlamp Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2000 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	2000 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	2000 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1999 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1999 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Mondeo	1998 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1998 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1998 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1997 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1997 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1997 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1997 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	BCM-B(Body Control Module B)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FDIM(Front Display Interface Module)																							V			
Ford	Mustang	3.7L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Mustang	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Mustang	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Mustang	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Mustang	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Mustang	3.7L	TiVCT	PSCM(Power Steering Control Module)																						V				
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.8L	SYSTEM SEARCH																											
Ford	Mustang	3.8L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.8L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.8L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.8L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.8L	RCM(Restraint Control Module)																											
Ford	Mustang	3.9L	SYSTEM SEARCH																											
Ford	Mustang	3.9L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.9L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.9L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.9L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.9L	RCM(Restraint Control Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	BCM-B(Body Control Module B)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																		V								
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FDIM(Front Display Interface Module)																							V			
Ford	Mustang	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.0L	V6 (SOHC)	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.0L	V6 (SOHC)	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Mustang	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Mustang	4.0L	V6 (SOHC)	PAM(Parking Aid Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PSCM(Power Steering Control Module)																						V				
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Mustang	4.0L	V6 (SOHC)	PATS(Passive Anti Theft System)-BETA																										
Ford	Mustang	4.6L	3V	SYSTEM SEARCH																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	BCM-B(Body Control Module B)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																		V								
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FDIM(Front Display Interface Module)																							V			
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	PATS(Passive Anti Theft System)-BETA																										
Ford	Mustang	5.0L	~ 2014	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FDIM(Front Display Interface Module)																						V			
Ford	Mustang	5.0L	~ 2014	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PSCM(Power Steering Control Module)																				V					
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM(Body Control Module)																	V								
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	C-CM(Cruise Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DACM-C(Digital Audio Control Module C)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DDM(Driver's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSM(Driver's Seat Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GWM(Gateway Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	HUD(Head Up Display)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ICM(Information Center Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-A(Movable Roof Control Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-B(Movable Roof Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PAM(Parking Aid Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PDM(Passenger's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Mustang	5.0L	2015 ~	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	RTM(Radio Transceiver Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCM-E(Seat Control Module E)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Mustang	5.4L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	BCM-B(Body Control Module B)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																		V								
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FDIM(Front Display Interface Module)																							V			
Ford	Mustang	5.4L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.4L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.4L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.4L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.4L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.4L	4V	PSCM(Power Steering Control Module)																						V				
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	BCM-B(Body Control Module B)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																		V								
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FDIM(Front Display Interface Module)																							V			
Ford	Mustang	5.8L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.8L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.8L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.8L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.8L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.8L	4V	PAM(Parking Aid Module)																										
Ford	Mustang	5.8L	4V	PSCM(Power Steering Control Module)																					V					
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																			V		V					
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM-B(Body Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ICM(Information Center Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-A(Movable Roof Control Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-B(Movable Roof Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)							V																			
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																	V									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																			V							
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Diesel(WL-CD)	SYSTEM SEARCH																											
Ford	Ranger	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.0 Diesel(WE-CD)	SYSTEM SEARCH																											
Ford	Ranger	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Ranger	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																	V									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																			V							
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Gasoline	SYSTEM SEARCH																											
Ford	Ranger	2.5 Gasoline	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Gasoline	ABS(Anti-Lock Brake System)																		V									
Ford	Ranger	2.5 Gasoline	ACM(Audio Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Ranger	2.5 Gasoline	BCMii(Body Control Module)																				V							
Ford	Ranger	2.5 Gasoline	DDM(Driver's Door Module)																											
Ford	Ranger	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																											
Ford	Ranger	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Ranger	2.5 Gasoline	IPC(Instrument Panel Control Module)																											
Ford	Ranger	2.5 Gasoline	PAM(Parking Aid Module)																											
Ford	Ranger	2.5 Gasoline	PDM(Passenger's Door Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	SRM(Speech Recognition Module)																											
Ford	Ranger	2.5 Gasoline	TBM(Tracking And Blocking Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TRM(Trailer Module)																											
Ford	Ranger	2.5 Gasoline	PATS(Passive Anti Theft System)-BETA																											
Ford	Ranger	3.0L	Other	SYSTEM SEARCH																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	Other	IC(Instrument Cluster)																										
Ford	Ranger	3.0L	Other	OCSM(Occupant Classification System Module)																										
Ford	Ranger	3.0L	Other	4X4(4x4 Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	3.0L	FFV	SYSTEM SEARCH																										
Ford	Ranger	3.0L	FFV	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	FFV	PATS(Passive Anti Theft System)																										
Ford	Ranger	3.0L	FFV	RAP(Remote Anti-Theft/Personality Module)																										
Ford	Ranger	3.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Ranger	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Ranger	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Ranger	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Ranger	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	4X4(4x4 Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	IC(Instrument Cluster)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	LTM(Liftgate/Trunk Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SECM(Steering Effort Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	C-CM(Cruise Control Module)		V																							
Ford	Taurus	3.5L	4V	2010 ~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																	V								
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HUD(Head Up Display)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	BCM(Body Control Module)	V																								
Ford	Taurus	3.5L	TiVCT	2013 ~	C-CM(Cruise Control Module)		V	V																						
Ford	Taurus	3.5L	TiVCT	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Taurus	3.5L	TiVCT	2013 ~	GFM(Generic Function Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RACM(Rear Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SCCM(Steering Column Control Module)						V																			
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	C-CM(Cruise Control Module)		V																							
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																V								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FDIM(Front Display Interface Module)																						V		
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GPSM(Global Positioning System Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM(Headlamp Control Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.0L	2000 ~	SYSTEM SEARCH																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	2000 ~	EATC(Electronic Automatic Temperature Control)																										
Ford	Taurus	3.0L	2000 ~	GEM(Generic Electronic Module)																										
Ford	Taurus	3.0L	2000 ~	IC(Instrument Cluster)																										
Ford	Taurus	3.0L	2000 ~	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	SYSTEM SEARCH																										
Ford	Taurus	3.0L	~ 1999	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	~ 1999	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	~ 1999	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	RIM(Remote Immobilizer Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)		V																								
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)			V																							
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)					V																					
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SYSTEM SEARCH																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PCM(PowerTrain Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ABS(Anti-Lock Brake System)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ACM(Audio Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	GEM(Generic Electronic Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	IC(Instrument Cluster)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PAM(Parking Aid Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	RCM(Restraint Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SRM(Speech Recognition Module)																										
Ford	Transit	2.0L	2001 ~ 2004	SYSTEM SEARCH																										
Ford	Transit	2.0L	2001 ~ 2004	PCM(PowerTrain Control Module)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.0L	2001 ~ 2004	ASM(Auto Shift Manual)																										
Ford	Transit	2.0L	2001 ~ 2004	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.0L	2001 ~ 2004	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																									V	
Ford	Transit	2.3L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																									V	
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	CSM(Central Security Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2006.5	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	ABS(Anti-Lock Brake System)																									V	
Ford	Transit	2.4L DIESEL	2006.5	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	2.4L DIESEL	2006.5	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	PAM(Parking Aid Module)																										
Ford	Transit	2.4L DIESEL	2006.5	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	TBM(Tracking And Blocking Module)																										
Ford	Transit	2.5L DIESEL	SYSTEM SEARCH																											
Ford	Transit	2.5L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	ASM(Auto Shift Manual)																											
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																										
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Transit	2.5L DIESEL	RCM(Restraint Control Module)																											
Ford	Transit	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Transit	2.5L DIESEL	CSM(Central Security Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	RIM(Remote Immobilizer Module)																											
Ford	Transit	2.5L DIESEL	ACM(Audio Control Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									V	
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																					V					
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Transit	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Transit	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Transit	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Transit	3.7L	TiVCT	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.7L	TiVCT	BCM(Body Control Module)																					V					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Ford	Transit	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Transit	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.7L	TiVCT	IPM-A(Image Processing Module A)																										
Ford	Transit	3.7L	TiVCT	IPM-B(Image Processing Module B)																										
Ford	Transit	3.7L	TiVCT	PAM(Park Aid Module)																										
Ford	Transit	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Transit	3.7L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.7L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.7L	TiVCT	TRM(Trailer Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Thunderbird	3.9L	4V	SYSTEM SEARCH																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ACM(Audio Control Module)																										
Ford	Thunderbird	3.9L	4V	DDM(Driver's Door Module)																										
Ford	Thunderbird	3.9L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Thunderbird	3.9L	4V	GEM(Generic Electronic Module)																										
Ford	Thunderbird	3.9L	4V	HEC(Hybrid Electrical Cluster)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	REM(Rear Electronic Module)																										
Lincoln	Aviator	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Aviator	4.6L	4V	PCM(Powertrain Control Module)																										
Lincoln	Aviator	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Aviator	4.6L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Aviator	4.6L	4V	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	Aviator	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Aviator	4.6L	4V	IC(Instrument Cluster)																										
Lincoln	Aviator	4.6L	4V	PAM(Parking Aid Module)																										
Lincoln	Aviator	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Aviator	4.6L	4V	TPM(Tire Pressure Monitor)																										
Lincoln	Aviator	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Lincoln	Aviator	4.6L	4V	VSM(Vehicle Security Module)																										
Lincoln	Continental	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Continental	4.6L	4V	PCM(PowerTrain Control Module)																										
Lincoln	Continental	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Continental	4.6L	4V	ACM(Audio Control Module)																										
Lincoln	Continental	4.6L	4V	CPM(Cellular Phone Module)																										
Lincoln	Continental	4.6L	4V	DDM(Driver's Door Module)																										
Lincoln	Continental	4.6L	4V	DSM(Driver's Seat Module)																										
Lincoln	Continental	4.6L	4V	LCM(Lighting Control Module)																										
Lincoln	Continental	4.6L	4V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Continental	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Continental	4.6L	4V	VDM(Vehicle Dynamic Module)																										
Lincoln	Continental	4.6L	4V	VIC(Virtual Image Cluster)																										
Lincoln	Continental	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Continental	4.6L	4V	PATS(Passive Anti Theft System)										V	V															
Lincoln	LS	ALL	SYSTEM SEARCH																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	ABS(Anti-Lock Brake System)																											
Lincoln	LS	ALL	DCSM(Driver-Dual Climate Control Seat Module)																											
Lincoln	LS	ALL	DDM(Driver's Door Module)																											
Lincoln	LS	ALL	DSM(Driver's Seat Module)																											
Lincoln	LS	ALL	EPB(Electronic Parking Brake)																											
Lincoln	LS	ALL	PAM(Parking Aid Module)																											
Lincoln	LS	ALL	RCM(Restraint Control Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	SCLM(Steering Column Locking Module)																											
Lincoln	LS	ALL	EATC(Electronic Automatic Temperature Control)																											
Lincoln	LS	ALL	GEM(Generic Electronic Module)																											
Lincoln	LS	ALL	HEC(Hybrid Electrical Cluster)																											
Lincoln	LS	ALL	PCSM(Passenger Climate Control Seat Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	MKS	3.7L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKS	3.7L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	C-CM(Cruise Control Module)		V																							
Lincoln	MKS	3.7L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	FDIM(Front Display Interface Module)																						V			
Lincoln	MKS	3.7L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.7L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2009	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2009	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2009	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2010 ~	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2010 ~	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	C-CM(Cruise Control Module)		V																							
Lincoln	MKS	3.7L	4V	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FDIM(Front Display Interface Module)																						V			
Lincoln	MKS	3.7L	4V	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	MKS	3.7L	4V	2010 ~	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2010 ~	HUD(Head Up Display)																									
Lincoln	MKS	3.7L	4V	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2010 ~	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	C-CM(Cruise Control Module)		V																							
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																V								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FDIM(Front Display Interface Module)																						V		
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GPSM(Global Positioning System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM(Headlamp Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM-2(Headlamp Control Module2)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HUD(Head Up Display)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC(Heating Ventilation Air Conditioning)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	C-CM(Cruise Control Module)		V																							
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																V								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDIM(Front Display Interface Module)																						V		
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GPSM(Global Positioning System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM(Headlamp Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM-2(Headlamp Control Module2)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HUD(Head Up Display)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC(Heating Ventilation Air Conditioning)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ILCM(Interior Lighting Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC(Instrument Panel Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	C-CM(Cruise Control Module)		V																							
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																V								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FDIM(Front Display Interface Module)																						V		
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GPSM(Global Positioning System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM(Headlamp Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM-2(Headlamp Control Module2)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HUD(Head Up Display)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HVAC(Heating Ventilation Air Conditioning)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ILCM(Interior Lighting Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	IPC(Instrument Panel Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PAM(Parking Aid Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PSCM(Power Steering Control Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKX	3.5L	4V	2007	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2007	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2007	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2007	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2007	EATC(Electronic Automatic Temperature Control)																									
Lincoln	MKX	3.5L	4V	2007	GEM(Generic Electronic Module)																									
Lincoln	MKX	3.5L	4V	2007	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2007	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2007	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2007	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2007	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2007	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2007	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2007	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2007	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2008	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2008	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2008	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2008	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2008	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2008	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	MKX	3.5L	4V	2008	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2008	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2008	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2008	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2008	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2008	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2008	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2008	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2008	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2009	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2009	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2009	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2009	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2009	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2010	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2010	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2010	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	MKX	3.5L	4V	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2010	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2010	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2010	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2010	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2010	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2010	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2010	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKZ	3.0L	2006	SYSTEM SEARCH																										
Lincoln	MKZ	3.0L	2006	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.0L	2006	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.0L	2006	ACM(Audio Control Module)																										
Lincoln	MKZ	3.0L	2006	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.0L	2006	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.0L	2006	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.0L	2006	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.0L	2006	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.0L	2006	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.0L	2006	IC(Instrument Cluster)																										
Lincoln	MKZ	3.0L	2006	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.0L	2006	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.0L	2006	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2007	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2007	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2007	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2007	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2007	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2007	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2007	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	MKZ	3.5L	2007	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2007	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.5L	2007	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.5L	2007	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2007	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2007	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2007	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2007	PATS(Passive Anti Theft System)																										
Lincoln	MKZ	3.5L	2008	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2008	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2008	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2008	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2008	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2008	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2008	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2008	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2008	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2008	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2008	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2008	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2008	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2008	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2008	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2008	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2009	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2009	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2009	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2009	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2009	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2009	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2009	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2009	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2009	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	MKZ	3.5L	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2009	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2009	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2009	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2009	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2009	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2009	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2009	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2010	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2010	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2010	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2010	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2010	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2010	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2010	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2010	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2010	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	3.5L	2010	FDIM(Front Display Interface Module)																							V			
Lincoln	MKZ	3.5L	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2010	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	3.5L	2010	HCM(Headlamp Control Module)																										
Lincoln	MKZ	3.5L	2010	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2010	ILCM(Interior Lighting Control Module)																										
Lincoln	MKZ	3.5L	2010	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	3.5L	2010	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2010	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2010	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2010	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	3.5L	2010	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	3.5L	2010	TCM(Transmission Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																			V							
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)						V																				
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRCM(Transmission Range Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM(Body Control Module)																			V							
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM(Steering Column Control Module)						V																				
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM(Transmission Range Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Lincoln	Navigator	2007 ~	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	APIM(Accessory Protocol Interface Module)																										
Lincoln	Navigator	2007 ~	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GPSM(Global Positioning System Module)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	2007 ~	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	2007 ~	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	2007 ~	5.4L	PRB(Power Running Board)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCU(Audio Rear Control Unit)																										
Lincoln	Navigator	2007 ~	5.4L	RETM(Rear Entertainment Module)																										
Lincoln	Navigator	2007 ~	5.4L	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	Navigator	2007 ~	5.4L	TCCM(Transfer Case Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	TCM(Transmission Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	2007 ~	5.4L	4X4(4x4 Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PATS(Passive Anti Theft System)																										
Lincoln	Navigator	~ 2007	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	GEM(Generic Electronic Module)																										
Lincoln	Navigator	~ 2007	5.4L	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Navigator	~ 2007	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	~ 2007	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	~ 2007	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	~ 2007	5.4L	RIM(Remote Immobilizer Module)																										
Lincoln	Navigator	~ 2007	5.4L	VSM(Vehicle Security Module)																										
Lincoln	Town Car	4.6L	2V	SYSTEM SEARCH																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	LCM(Lighting Control Module)																										
Lincoln	Town Car	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Lincoln	Town Car	4.6L	2V	DDM(Driver's Door Module)																										
Lincoln	Town Car	4.6L	2V	DSM(Driver's Seat Module)																										
Lincoln	Town Car	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Town Car	4.6L	2V	RATC(Rear Air Temperature Control)																										
Lincoln	Town Car	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Lincoln	Town Car	4.6L	2V	PAM(Parking Aid Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	HEC(Hybrid Electrical Cluster)																										
Lincoln	Town Car	4.6L	2V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Town Car	4.6L	2V	RASM(Rear Air Suspension Module)																										
Mercury	Grand Marquis	4.6L	2V	SYSTEM SEARCH																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	DDM(Driver's Door Module)																										
Mercury	Grand Marquis	4.6L	2V	IC(Instrument Cluster)																										
Mercury	Grand Marquis	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Grand Marquis	4.6L	2V	LCM(Lighting Control Module)																										
Mercury	Grand Marquis	4.6L	2V	MC(Message Center)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RIM(Remote Immobilizer Module)																										
Mercury	Grand Marquis	4.6L	2V	GEM(Generic Electronic Module)																										
Mercury	Grand Marquis	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Mercury	Marauder	4.6L	4V	SYSTEM SEARCH																										
Mercury	Marauder	4.6L	4V	PCM(Powertrain Control Module)																										
Mercury	Marauder	4.6L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Marauder	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Marauder	4.6L	4V	RASM(Rear Air Suspension Module)																										
Mercury	Marauder	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Mercury	Marauder	4.6L	4V	DDM(Driver's Door Module)																										
Mercury	Marauder	4.6L	4V	LCM(Lighting Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																							V			
Mercury	Milan	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	Milan	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																							V			
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SYSTEM SEARCH																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Milan	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	Milan	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	FDIM(Front Display Interface Module)																							V			
Mercury	Milan	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Milan	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	Milan	3.0L	4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Milan	3.0L	4V	PATS(Passive Anti Theft System)																										
Mercury	Montego	3.0L	4V	SYSTEM SEARCH																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Montego	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Montego	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Montego	3.0L	4V	DSM(Driver's Seat Module)																										
Mercury	Montego	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Montego	3.0L	4V	GEM(Generic Electronic Module)																										
Mercury	Montego	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Montego	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Montego	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Montego	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Mercury	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Mercury	Mountaineer	2010 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2010 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2010 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2010 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2010 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2010 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.6L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	Mountaineer	2009 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2009 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2009 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2009 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2009 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2008 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2008 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2008 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2008 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	Mountaineer	2007 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2007 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2007 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2007 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2007 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2006 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2006 MY	4.6L	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	Mountaineer	2006 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2006 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2006 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2006 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2006 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2003 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2003 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2003 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2003 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2003 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2003 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2003 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2002 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2002 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2002 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2002 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	Mountaineer	2002 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2002 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2001 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2001 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2001 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2001 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2001 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2001 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2000 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2000 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2000 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2000 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2000 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2000 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	1999 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1999 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1999 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1999 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1999 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1999 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	1998 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1998 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1998 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1998 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1998 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1997 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1997 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1997 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1997 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1997 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)															V	V	V									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																		V								
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																			V	V	V					
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																						V	V			
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)															V	V	V									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																			V	V	V					
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																						V	V			
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																							V			
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																								V	V
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																	V									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																								V	V
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	BMS Reset	CCM Calibration	CCM Module Installation	DCSM Module Installation	HVAC Module Installation	SCCM Module Installation	Ignition Key Programming	Ignition Key Code Erase	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Lateral Acceleration Sensor	Brake Fluid Pressure Sensor	Steering angle sensor	ActuationTest	Battery Monitoring System Reset	Wiper Motor Module Calibration	TPMS Sensor Training Mode	PDC Reset	Steering Wheel Position Sensor Calibration	FDIM Module Installation	Configure the steering angle sensor	Steering Torque Sensor Trim
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																		V								
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																								V	V
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Vehicle Info.	Vehicle Info.	Vehicle Info.																												
Ford	Crown Victoria	4.6L	2V	SYSTEM SEARCH																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	DDM(Driver's Door Module)																										
Ford	Crown Victoria	4.6L	2V	IC(Instrument Cluster)																										
Ford	Crown Victoria	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Crown Victoria	4.6L	2V	LCM(Lighting Control Module)																										
Ford	Crown Victoria	4.6L	2V	MC(Message Center)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	Crown Victoria	4.6L	2V	GEM(Generic Electronic Module)																										
Ford	Crown Victoria	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.4L	DIESEL	SYSTEM SEARCH																										
Ford	Ecosport	1.4L	DIESEL	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.4L	DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.4L	DIESEL	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.4L	DIESEL	IC(Instrument Cluster)																										
Ford	Ecosport	1.4L	DIESEL	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	FFV	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Ecosport	1.6L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	FFV	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Escort	2.0L	SYSTEM SEARCH																											
Ford	Escort	2.0L	PCM(PowerTrain Control Module)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ECS(Electronic Crash Sensor)																											
Ford	Escort	2.0L	PATS(Passive Anti Theft System)																											
Ford	Escort	2.0L	RAP(Remote Anti-Theft/Personality Module)																											
Ford	Edge	3.5L	4V	SYSTEM SEARCH																										
Ford	Edge	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Edge	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Edge	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Edge	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	4V	IC(Instrument Cluster)																										
Ford	Edge	3.5L	4V	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Edge	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Edge	3.5L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Edge	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.5L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.5L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	TiVCT	RFA(Remote Function Actuator)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Edge	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.5L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.5L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Edge	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.7L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.7L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.7L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.7L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.7L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.7L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Edge	3.7L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.7L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.7L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.7L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.7L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.7L	TiVCT	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.7L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Escape	Up to 2004	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Escape	Up to 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	Up to 2004	Immobilizer																											
Ford	Escape	Up to 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	Up to 2004	RCM(Restraint Control Module)																											
Ford	Escape	Up to 2004	GEM(Generic Electronic Module)																											
Ford	Escape	From 2004	SYSTEM SEARCH																											
Ford	Escape	From 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	From 2004	PATS(Passive Anti Theft System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	RCM(Restraint Control Module)																											
Ford	Escape	From 2004	IC(Instrument cluster)																											
Ford	Escape	From 2004	GEM(Generic Electronic Module)																											
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)		V																								
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)		V																								
Ford	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)		V																								
Ford	Excursion	GASOLINE	SYSTEM SEARCH																											
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											
Ford	Excursion	GASOLINE	ABS(Anti-Lock Brake System)																											
Ford	Excursion	GASOLINE	CSM(Central Security Module)																											
Ford	Excursion	GASOLINE	DSM(Driver's Seat Module)																											
Ford	Excursion	GASOLINE	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	GASOLINE	ECS(Electronic Crash Sensor)																											
Ford	Excursion	GASOLINE	GEM(Generic Electronic Module)																											
Ford	Excursion	GASOLINE	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	GASOLINE	OTC(Overhead Trip Computer)																											
Ford	Excursion	GASOLINE	PAM(Parking Aid Module)																											
Ford	Excursion	GASOLINE	PATS(Passive Anti Theft System)																											
Ford	Excursion	GASOLINE	TCM(Transmission Control Module)				V																							
Ford	Excursion	GASOLINE	VSM(Vehicle Security Module)																											
Ford	Excursion	DIESEL	SYSTEM SEARCH																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Excursion	DIESEL	CSM(Central Security Module)																											
Ford	Excursion	DIESEL	DSM(Driver's Seat Module)																											
Ford	Excursion	DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	DIESEL	ECS(Electronic Crash Sensor)																											
Ford	Excursion	DIESEL	GEM(Generic Electronic Module)																											
Ford	Excursion	DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	DIESEL	OTC(Overhead Trip Computer)																											
Ford	Excursion	DIESEL	PAM(Parking Aid Module)																											
Ford	Excursion	DIESEL	PATS(Passive Anti Theft System)																											
Ford	Excursion	DIESEL	TCM(Transmission Control Module)				V																							
Ford	Excursion	DIESEL	VSM(Vehicle Security Module)																											
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)			V																						
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DCSM(Driver-Dual Climate Control Seat Module)				V																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	EATC(Electronic Automatic Temperature Control)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	TCM(Transmission Control Module)		V																							
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PATS(Passive Anti Theft System)	V																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VSM(Vehicle Security Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)			V																						
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TBC(Trailer Brake Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCCM(Transfer Case Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCM(Transmission Control Module)		V																							
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PATS(Passive Anti Theft System)	V																								
Ford	ExpeditionExpedition EL	5.4L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DCSM(Driver-Dual Climate Control Seat Module)				V																						
Ford	ExpeditionExpedition EL	5.4L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	GEM(Generic Electronic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	5.4L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VSM(Vehicle Security Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	APIM(Accessory Protocol Interface Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DCSM(Driver-Dual Climate Control Seat Module)					V																					
Ford	ExpeditionExpedition EL	4.6L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GPSM(Global Positioning System Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	4.6L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PRB(Power Running Board)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCU(Audio Rear Control Unit)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RETM(Rear Entertainment Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	TCM(Transmission Control Module)			V																							
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	4X4(4x4 Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VSM(Vehicle Security Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2015 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Explorer	2015 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)					V																				
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)						V																			
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)							V																		
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Explorer	2014 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2014 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)					V																				
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)						V																			
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)							V																		
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Explorer	2013 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PATS(Passive Anti Theft System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)					V																				
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)						V																			
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)							V																		
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2012 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Explorer	2012 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)					V																				
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)						V																			
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)							V																		
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Explorer	2011 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)					V																				
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)						V																			
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)							V																		
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	TCM(Transmission Control Module)		V																							
Ford	Explorer	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA	V																								
Ford	Explorer	2010 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	TCM(Transmission Control Module)		V																							
Ford	Explorer	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.6L	3V	IC(Instrument Cluster)								V																	
Ford	Explorer	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	TCM(Transmission Control Module)		V																							
Ford	Explorer	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA	V																								
Ford	Explorer	2009 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	TCM(Transmission Control Module)		V																							
Ford	Explorer	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.6L	3V	IC(Instrument Cluster)								V																	
Ford	Explorer	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	TCM(Transmission Control Module)		V																							
Ford	Explorer	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.0L	2V	IC(Instrument Cluster)									V	V															
Ford	Explorer	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	TCM(Transmission Control Module)		V																							
Ford	Explorer	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	TCM(Transmission Control Module)		V																							
Ford	Explorer	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.0L	2V	IC(Instrument Cluster)									V	V															
Ford	Explorer	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	TCM(Transmission Control Module)		V																							
Ford	Explorer	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	TCM(Transmission Control Module)		V																							
Ford	Explorer	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.0L	2V	IC(Instrument Cluster)									V	V															
Ford	Explorer	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	TCM(Transmission Control Module)		V																							
Ford	Explorer	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2005 MY	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2005 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2005 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2005 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2005 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2005 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2004 MY	SYSTEM SEARCH																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2004 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2004 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2004 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2004 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2004 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2003 MY	SYSTEM SEARCH																											
Ford	Explorer	2003 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2003 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2003 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2003 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2003 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2003 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2003 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2002 MY	SYSTEM SEARCH																											
Ford	Explorer	2002 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2002 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2002 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2002 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2002 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2002 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2002 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2001 MY	SYSTEM SEARCH																											
Ford	Explorer	2001 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2001 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2001 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2001 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer	2001 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2001 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	SYSTEM SEARCH																											
Ford	Explorer	2000 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2000 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2000 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	2000 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2000 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	1999 MY	SYSTEM SEARCH																											
Ford	Explorer	1999 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1999 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1999 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1999 MY	PAM(Parking Aid Module)																											
Ford	Explorer	1998 MY	SYSTEM SEARCH																											
Ford	Explorer	1998 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1998 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1998 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1998 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1997 MY	SYSTEM SEARCH																											
Ford	Explorer	1997 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1997 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1997 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1997 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	TCM(Transmission Control Module)		V																							
Ford	Explorer SportTrac	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer SportTrac	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA	V																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	TCM(Transmission Control Module)		V																							
Ford	Explorer SportTrac	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	IC(Instrument Cluster)								V																	
Ford	Explorer SportTrac	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	TCM(Transmission Control Module)		V																							
Ford	Explorer SportTrac	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer SportTrac	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA	V																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	TCM(Transmission Control Module)		V																							
Ford	Explorer SportTrac	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	IC(Instrument Cluster)								V																	
Ford	Explorer SportTrac	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	TCM(Transmission Control Module)		V																							
Ford	Explorer SportTrac	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer SportTrac	2008 MY	4.0L	2V	IC(Instrument Cluster)									V	V															
Ford	Explorer SportTrac	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	TCM(Transmission Control Module)		V																							
Ford	Explorer SportTrac	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	TCM(Transmission Control Module)		V																							
Ford	Explorer SportTrac	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	IC(Instrument Cluster)									V	V															
Ford	Explorer SportTrac	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	TCM(Transmission Control Module)		V																							
Ford	Explorer SportTrac	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	TCM(Transmission Control Module)		V																							
Ford	Explorer SportTrac	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	IC(Instrument Cluster)									V	V															
Ford	Explorer SportTrac	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	TCM(Transmission Control Module)		V																							
Ford	Explorer SportTrac	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2004 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	RAP(Remote Anti-Theft/Personality Module)																									
Ford	E-Series	5.4L	2V	2004 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2004 ~	VSM(Vehicle Security Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	ABS(Anti-Lock Brake System)											V	V													
Ford	E-Series	5.4L	2V	2009 ~	ACM(Audio Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	E-Series	5.4L	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	E-Series	5.4L	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	E-Series	5.4L	2V	2009 ~	IPC(Instrument Panel Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)												V														
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)														V	V											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																										
Ford	F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)												V														
Ford	F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)														V	V											
Ford	F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																										
Ford	F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)											V														
Ford	F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)		V																							
Ford	F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)															V	V									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																									
Ford	F150	4.6L(BETA)	3V	SYSTEM SEARCH																										
Ford	F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																										
Ford	F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)												V														
Ford	F150	4.6L(BETA)	3V	ACM(Audio Control Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)				V																						
Ford	F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																										
Ford	F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																										
Ford	F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																										
Ford	F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	4.6L(BETA)	3V	IC(Instrument Cluster)																										
Ford	F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																										
Ford	F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																										
Ford	F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																										
Ford	F150	4.6L(BETA)	3V	PRB(Power Running Board)																										
Ford	F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																										
Ford	F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCM(Transmission Control Module)			V																							
Ford	F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																										
Ford	F150	5.0L	TiVCT	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	F150	5.0L	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)												V														
Ford	F150	5.0L	TiVCT	ACM(Audio Control Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)					V																					
Ford	F150	5.0L	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	5.0L	TiVCT	IC(Instrument Cluster)																										
Ford	F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PRB(Power Running Board)																										
Ford	F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	5.0L	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	5.0L	TiVCT	TCM(Transmission Control Module)			V																							
Ford	F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	F150	5.4L	3V	2009 ~	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)											V														
Ford	F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)				V																					

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2009 ~	PRB(Power Running Board)																									
Ford	F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)		V																							
Ford	F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)															V	V									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	6.2L(BETA)	2V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																										
Ford	F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)												V														
Ford	F150	6.2L(BETA)	2V	ACM(Audio Control Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																										
Ford	F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																										
Ford	F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																										
Ford	F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																										
Ford	F150	6.2L(BETA)	2V	IC(Instrument Cluster)																										
Ford	F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																										
Ford	F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																										
Ford	F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																										
Ford	F150	6.2L(BETA)	2V	PRB(Power Running Board)																										
Ford	F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																										
Ford	F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCM(Transmission Control Module)			V																							
Ford	F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																										
Ford	F150	Other	2004 ~ 2008	SYSTEM SEARCH																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																										
Ford	F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																										
Ford	F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																										
Ford	F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	Other	2004 ~ 2008	IC(Instrument Cluster)																										
Ford	F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																V	V									
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										
Ford	F250	7.3L	SYSTEM SEARCH																											
Ford	F250	7.3L	PCM(PowerTrain Control Module)																			V	V	V						
Ford	F250	7.3L	ABS(Anti-Lock Brake System)																											
Ford	F250	7.3L	ECS(Electronic Crash Sensor)																											
Ford	F250	7.3L	GEM(Generic Electronic Module)																											
Ford	F250	6.2L	SYSTEM SEARCH																											
Ford	F250	6.2L	PCM(Powertrain Control Module)																											
Ford	F250	6.2L	ABS(Anti-Lock Brake System)																						V					
Ford	F250	6.2L	ACM(Audio Control Module)																											
Ford	F250	6.2L	APIM(Accessory Protocol Control Module)																											
Ford	F250	6.2L	BCMii(Body Control Module)																											
Ford	F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																											
Ford	F250	6.2L	DSM(Driver Seat Module)																											
Ford	F250	6.2L	GPSM(Global Positioning System Module)																											
Ford	F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F250	6.2L	IPC(Instrument Panel Control Module)																											
Ford	F250	6.2L	PAM(Parking Aid Module)																											
Ford	F250	6.2L	RCM(Restraint Control Module)																											
Ford	F250	6.2L	SCCM(Streering Colume Control Module)																											
Ford	F250	6.2L	TBC(Trailer Brake Control Module)																											
Ford	F250	6.2L	TCCM(Transfer Case Control Module)																											
Ford	F250	6.2L	TPM(Tire Pressure Monitor)																											
Ford	F250	6.0L	SYSTEM SEARCH																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.0L	GEM(Generic Electronic Module)																											
Ford	F250	6.0L	HEC(Hybrid Electrical Cluster)																											
Ford	F250	6.0L	OTC(Overhead Trip Computer)																											
Ford	F250	6.0L	PAM(Parking Aid Module)																											
Ford	F250	6.0L	PATS(Passive Anti Theft System)																											
Ford	F250	6.0L	RCM(Restraint Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)				V																							
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	VSM(Vehicle Security Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SYSTEM SEARCH																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM(PowerTrain Control Module)																						V	V	V	V	V
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4(4x4 Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS(Anti-Lock Brake System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM(Audio Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM(Auxiliary Heater Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM(Accessory Protocol Interface Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM(Circuit Deactivation Ignition Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM(Driver's Seat Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GPSM(Global Positioning System Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC(Instrument Cluster)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM(Parking Aid Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM(Restraint Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM(Rear Entertainment Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS(Satellite Digital Audio Receiver System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC(Trailer Brake Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM(Transmission Control Module)			V																							
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																									V
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																				V					
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)														V											
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																									V
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																				V					
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																									
Ford	Fiesta	1.4L	DURATEC 16V	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)												V														
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)												V														
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Fiesta	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)												V														
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	BCMii(Body Control Module)																										
Ford	Fiesta	1.6L	DURATEC	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)												V														
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	BCM(Body Control Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Fiesta	1.6L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.6L	TiVCT	VSM(Vehicle Security Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	ABS(Anti-Lock Brake System)												V														
Ford	Fiesta	1.6L	Zetec Rocam	IC(Instrument Cluster)																										
Ford	Fiesta	1.6L	Zetec Rocam	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	RKE(Remote Keyless Entry)																										
Ford	Fiesta	1.6L	Zetec Rocam	TCM(Transmission Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	SYSTEM SEARCH																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)												V														
Ford	Fiesta	2.0L	SYSTEM SEARCH																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)													V														
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	2.0L	ACM(Audio Control Module)																											
Ford	Fiesta	2.0L	EATC(Electronic Automatic Temperature Control)																											
Ford	Fiesta	2.0L	GEM(Generic Electronic Module)																											
Ford	Fiesta	2.0L	IC(Instrument Cluster)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	RCM(Restraint Control Module)																											
Ford	Fiesta	2.0L	PATS(Passive Anti Theft System)-BETA																											
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Focus	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)												V														
Ford	Focus	1.6L	ZETEC ROCAM	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Focus	1.6L	ZETEC ROCAM	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Focus	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic power steering)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ACM(Audio control module)																										
Ford	Focus	1.8L	DURATEC HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.8L	DURATEC HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.8L	DURATEC HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.8L	DURATEC HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.8L	DURATEC HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	IC(Instrument cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	NAV(Navigation System)																										
Ford	Focus	1.8L	DURATEC HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	MC(Message Center)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FDIM(Front Display Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TCM(Transmission control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CSM(Central Security Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EPS(Electronic power steering)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GDM(Generic Display Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	NAV(Navigation System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RKE(Remote Keyless Entry)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TBM(Tracking And Blocking Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SRM(Speech recognition module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SYSTEM SEARCH																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ACM(Audio Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	BCM(Body Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DDM(Driver's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	IPC(Instrument Panel Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PAM(Parking Aid Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PSCM(Power Steering Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SASM(Steering Angle Sensor Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Focus	2.0L DIESEL	2003 ~ 2008	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FACM(Fuel Additive Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RETM(Rear Entertainment Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RKE(Remote Keyless Entry)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	TCM(Transmission control module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	DDM(Driver's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	MC(Message Center)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ACM(Audio control module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Focus C-MAX	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Flex	3.5L	4V	SYSTEM SEARCH																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	4V	ABS(Anti-Lock Brake System)												V	V													
Ford	Flex	3.5L	4V	ACM(Audio control module)																										
Ford	Flex	3.5L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	4V	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	4V	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	4V	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	4V	IC(Instrument cluster)																										
Ford	Flex	3.5L	4V	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	4V	LTM(Liftgate/Trunk Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Flex	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	4V	Factory Keyless Entry Code																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)												V	V													
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio control module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC(Instrument cluster)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Flex	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	TiVCT	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	TiVCT	ABS(Anti-Lock Brake System)												V	V													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Flex	3.5L	TiVCT	ACM(Audio control module)																										
Ford	Flex	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	TiVCT	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	TiVCT	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	TiVCT	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	TiVCT	IC(Instrument cluster)																										
Ford	Flex	3.5L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	TiVCT	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Ford	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Ford	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Ford	Freestyle	3.0L	4V	SYSTEM SEARCH																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Freestyle	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Freestyle	3.0L	4V	ACM(Audio Control Module)																										
Ford	Freestyle	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Freestyle	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Freestyle	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Freestyle	3.0L	4V	IC(Instrument Cluster)																										
Ford	Freestyle	3.0L	4V	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Freestyle	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Freestyle	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Five Hundred	3.0L	4V	SYSTEM SEARCH																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Five Hundred	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Five Hundred	3.0L	4V	ACM(Audio Control Module)																										
Ford	Five Hundred	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Five Hundred	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Five Hundred	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Five Hundred	3.0L	4V	IC(Instrument Cluster)																										
Ford	Five Hundred	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Five Hundred	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Five Hundred	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Ford GT	5.4L	4V	SYSTEM SEARCH																										
Ford	Ford GT	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	IC(Instrument Cluster)																										
Ford	Ford GT	5.4L	4V	PATS(Passive Anti Theft System)																										
Ford	Ford GT	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)											V															
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	TCM(Transmission control module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Fusion	1.6L	DURATEC	ABS(Anti-Lock Brake System)												V														
Ford	Fusion	1.6L	DURATEC	IC(Instrument cluster)																										
Ford	Fusion	1.6L	DURATEC	ACM(Audio control module)																										
Ford	Fusion	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fusion	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)												V														
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)												V														
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SYSTEM SEARCH																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)												V														
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BCM(Body Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HUD(Head Up Display)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPM-A(Image Processing Module A)						V																				
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM(Secondary OBD Control Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	TCU(Telematic Control Unit Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)										V	V															
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)		V																								
Ford	Fusion	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Fusion	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)								V																		
Ford	Fusion	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.5L	IVCT	SYSTEM SEARCH																										
Ford	Fusion	2.5L	IVCT	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	IVCT	ABS(Anti-Lock Brake System)												V														
Ford	Fusion	2.5L	IVCT	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	IVCT	BCM(Body Control Module)																										
Ford	Fusion	2.5L	IVCT	C-CM(Cruise Control Module)																										
Ford	Fusion	2.5L	IVCT	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.5L	IVCT	DDM(Driver's Door Module)																										
Ford	Fusion	2.5L	IVCT	DSM(Driver's Seat Module)																										
Ford	Fusion	2.5L	IVCT	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	IVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.5L	IVCT	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	IVCT	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	IVCT	GWM(Gateway Module A)																										
Ford	Fusion	2.5L	IVCT	HUD(Head Up Display)																										
Ford	Fusion	2.5L	IVCT	IPC(Instrument Panel Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Fusion	2.5L	IVCT	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.5L	IVCT	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	IVCT	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	IVCT	PDM(Passenger's Door Module)																										
Ford	Fusion	2.5L	IVCT	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	IVCT	RACM(Rear Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	IVCT	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.5L	IVCT	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.5L	IVCT	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.5L	IVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	IVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)										V	V															
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.0L	4V	PSCM(Power Steering Control Module)								V																		
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.0L	4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	3.0L	4V	PATS(Passive Anti Theft System)		V																								
Ford	Fusion	3.5L	4V	SYSTEM SEARCH																										
Ford	Fusion	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.5L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.5L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.5L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.5L	4V	PSCM(Power Steering Control Module)								V																		
Ford	Fusion	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.5L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.5L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	KA	2000 MY	SYSTEM SEARCH																											
Ford	KA	2000 MY	PCM(PowerTrain Control Module)																											
Ford	KA	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	KA	2000 MY	RCM(Restraint Control Module)																											
Ford	KA	1999 MY	PCM(PowerTrain Control Module)																											
Ford	KA	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Kuga	2.0L DIESEL	SYSTEM SEARCH																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Kuga	2.0L DIESEL	TCM(Transmission Control Module)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																											
Ford	Kuga	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																											
Ford	Kuga	2.0L DIESEL	AWD(All Wheel Drive Module)																											
Ford	Kuga	2.0L DIESEL	BCMii(Body Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Kuga	2.0L DIESEL	CCMii(Cruise Control Module)																											
Ford	Kuga	2.0L DIESEL	CMR(Camera Module Rear)																											
Ford	Kuga	2.0L DIESEL	D_DCU(Driver Door Control Unit)																											
Ford	Kuga	2.0L DIESEL	DDM(Driver's Door Module)																											
Ford	Kuga	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Kuga	2.0L DIESEL	EPS(Electronic Power Steering)																											
Ford	Kuga	2.0L DIESEL	FDSM(Front Distance Sensing Module)																											
Ford	Kuga	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																											
Ford	Kuga	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Kuga	2.0L DIESEL	GEM(Generic Electronic Module)																											
Ford	Kuga	2.0L DIESEL	GPSM(Global Positioning System Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Kuga	2.0L DIESEL	IPM-A(Image Processing Module A)																											
Ford	Kuga	2.0L DIESEL	IPM-B(Image Processing Module B)																											
Ford	Kuga	2.0L DIESEL	IPC(Instrument Panel Control Module)																											
Ford	Kuga	2.0L DIESEL	IC(Instrument Cluster)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PSCM(Power Steering Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RFA(Remote Function Actuator)																											
Ford	Kuga	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																											
Ford	Kuga	2.0L DIESEL	RETM(Rear Entertainment Module)																											
Ford	Kuga	2.0L DIESEL	SASM(Steering Angle Sensor Module)																											
Ford	Kuga	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Kuga	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Kuga	2.0L DIESEL	SRM(Speech Recognition Module)																											
Ford	Kuga	2.0L DIESEL	TRM(Trailer Module)																											
Ford	Kuga	2.5L	I5	SYSTEM SEARCH																										
Ford	Kuga	2.5L	I5	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.5L	I5	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.5L	I5	ACM(Audio Control Module)																										
Ford	Kuga	2.5L	I5	AWD(All Wheel Drive Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Kuga	2.5L	I5	CMR(Camera Module Rear)																										
Ford	Kuga	2.5L	I5	D_DCU(Driver Door Control Unit)																										
Ford	Kuga	2.5L	I5	EATC(Electronic Automatic Temperature Control)																										
Ford	Kuga	2.5L	I5	EPS(Electronic Power Steering)																										
Ford	Kuga	2.5L	I5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Kuga	2.5L	I5	GEM(Generic Electronic Module)																										
Ford	Kuga	2.5L	I5	HCM(Headlamp Control Module)																										
Ford	Kuga	2.5L	I5	IC(Instrument Cluster)																										
Ford	Kuga	2.5L	I5	PAM(Parking Aid Module)																										
Ford	Kuga	2.5L	I5	PDM(Passenger's Door Module)																										
Ford	Kuga	2.5L	I5	RCM(Restraint Control Module)																										
Ford	Kuga	2.5L	I5	RETM(Rear Entertainment Module)																										
Ford	Kuga	2.5L	I5	RKE(Remote Keyless Entry)																										
Ford	Kuga	2.5L	I5	SRM(Speech Recognition Module)																										
Ford	Kuga	2.5L	I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Mondeo	2010 MY	2.5L I5	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.5L I5	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.5L I5	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.5L I5	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.5L I5	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.5L I5	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.5L I5	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.5L I5	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SYSTEM SEARCH																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	AHCM(Auxiliary Heater Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	BCMii(Body Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CCMii(Cruise Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DDM(Driver's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DSM(Driver's Seat Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HCM(HeadLamp Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RFA(Remote Function Actuator)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TRM(Trailer Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ACM(Audio Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	CDP(Compact Disc Player)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GDM(Generic Display Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	NAV(Navigation System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SRM(Speech Recognition Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	SYSTEM SEARCH																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	GEM(Generic Electronic Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	HCM(Headlamp Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2000 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	2000 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	2000 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1999 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1999 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Mondeo	1998 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1998 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1998 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1997 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1997 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1997 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1997 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																					V					
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	BCM-B(Body Control Module B)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Mustang	3.7L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Mustang	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Mustang	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Mustang	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Mustang	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Mustang	3.7L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.8L	SYSTEM SEARCH																											
Ford	Mustang	3.8L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.8L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.8L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.8L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.8L	RCM(Restraint Control Module)																											
Ford	Mustang	3.9L	SYSTEM SEARCH																											
Ford	Mustang	3.9L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.9L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.9L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.9L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.9L	RCM(Restraint Control Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																					V					
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	BCM-B(Body Control Module B)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.0L	V6 (SOHC)	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.0L	V6 (SOHC)	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Mustang	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Mustang	4.0L	V6 (SOHC)	PAM(Parking Aid Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PSCM(Power Steering Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Mustang	4.0L	V6 (SOHC)	PATS(Passive Anti Theft System)-BETA											V															
Ford	Mustang	4.6L	3V	SYSTEM SEARCH																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)												V														
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																					V					
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	BCM-B(Body Control Module B)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	PATS(Passive Anti Theft System)-BETA											V															
Ford	Mustang	5.0L	~ 2014	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																				V					
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FDIM(Front Display Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ABS(Anti-Lock Brake System)											V														
Ford	Mustang	5.0L	2015 ~	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM(Body Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	C-CM(Cruise Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DACM-C(Digital Audio Control Module C)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DDM(Driver's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSM(Driver's Seat Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSP(Digital Signal Processing Module)					V																				
Ford	Mustang	5.0L	2015 ~	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GWM(Gateway Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	HUD(Head Up Display)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ICM(Information Center Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-A(Movable Roof Control Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-B(Movable Roof Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PAM(Parking Aid Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PDM(Passenger's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Mustang	5.0L	2015 ~	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	RTM(Radio Transceiver Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCM-E(Seat Control Module E)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Mustang	5.4L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																					V					
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	BCM-B(Body Control Module B)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.4L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.4L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.4L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.4L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.4L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.4L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																					V					
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	BCM-B(Body Control Module B)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.8L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.8L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.8L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.8L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.8L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.8L	4V	PAM(Parking Aid Module)																										
Ford	Mustang	5.8L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)												V														
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM-B(Body Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)						V																				
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ICM(Information Center Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-A(Movable Roof Control Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-B(Movable Roof Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)										V																
Ford	Ranger	2.5 Diesel(WL-CD)	SYSTEM SEARCH																											
Ford	Ranger	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	PATS(Passive Anti Theft System)											V																
Ford	Ranger	3.0 Diesel(WE-CD)	SYSTEM SEARCH																											
Ford	Ranger	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Ranger	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	PATS(Passive Anti Theft System)											V																
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)										V																
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)												V														
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PATS(Passive Anti Theft System)		V																								
Ford	Ranger	2.5 Gasoline	SYSTEM SEARCH																											
Ford	Ranger	2.5 Gasoline	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Gasoline	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Gasoline	ACM(Audio Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Ranger	2.5 Gasoline	BCMii(Body Control Module)																											
Ford	Ranger	2.5 Gasoline	DDM(Driver's Door Module)																											
Ford	Ranger	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																											
Ford	Ranger	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Ranger	2.5 Gasoline	IPC(Instrument Panel Control Module)																											
Ford	Ranger	2.5 Gasoline	PAM(Parking Aid Module)																											
Ford	Ranger	2.5 Gasoline	PDM(Passenger's Door Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	SRM(Speech Recognition Module)																											
Ford	Ranger	2.5 Gasoline	TBM(Tracking And Blocking Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TRM(Trailer Module)																											
Ford	Ranger	2.5 Gasoline	PATS(Passive Anti Theft System)-BETA											V																
Ford	Ranger	3.0L	Other	SYSTEM SEARCH																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)												V														
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	Other	IC(Instrument Cluster)																										
Ford	Ranger	3.0L	Other	OCSM(Occupant Classification System Module)																										
Ford	Ranger	3.0L	Other	4X4(4x4 Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	3.0L	FFV	SYSTEM SEARCH																										
Ford	Ranger	3.0L	FFV	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	FFV	PATS(Passive Anti Theft System)		V																								
Ford	Ranger	3.0L	FFV	RAP(Remote Anti-Theft/Personality Module)																										
Ford	Ranger	3.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Ranger	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Ranger	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)												V														
Ford	Ranger	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Ranger	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	4X4(4x4 Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	IC(Instrument Cluster)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	LTM(Liftgate/Trunk Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SECM(Steering Effort Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Taurus	3.5L	4V	2010 ~ 2012	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HUD(Head Up Display)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	BCM(Body Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Taurus	3.5L	TiVCT	2013 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Taurus	3.5L	TiVCT	2013 ~	GFM(Generic Function Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PSCM(Power Steering Control Module)							V																		
Ford	Taurus	3.5L	TiVCT	2013 ~	RACM(Rear Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SCCM(Steering Column Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.0L	2000 ~	SYSTEM SEARCH																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	ABS(Anti-Lock Brake System)												V														
Ford	Taurus	3.0L	2000 ~	EATC(Electronic Automatic Temperature Control)																										
Ford	Taurus	3.0L	2000 ~	GEM(Generic Electronic Module)																										
Ford	Taurus	3.0L	2000 ~	IC(Instrument Cluster)																										
Ford	Taurus	3.0L	2000 ~	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	SYSTEM SEARCH																										
Ford	Taurus	3.0L	~ 1999	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	~ 1999	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	~ 1999	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	RIM(Remote Immobilizer Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)							V																			
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SYSTEM SEARCH																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PCM(PowerTrain Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ABS(Anti-Lock Brake System)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ACM(Audio Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	GEM(Generic Electronic Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	IC(Instrument Cluster)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PAM(Parking Aid Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	RCM(Restraint Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SRM(Speech Recognition Module)																										
Ford	Transit	2.0L	2001 ~ 2004	SYSTEM SEARCH																										
Ford	Transit	2.0L	2001 ~ 2004	PCM(PowerTrain Control Module)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.0L	2001 ~ 2004	ASM(Auto Shift Manual)																										
Ford	Transit	2.0L	2001 ~ 2004	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.0L	2001 ~ 2004	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	CSM(Central Security Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2006.5	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2006.5	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	2.4L DIESEL	2006.5	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	PAM(Parking Aid Module)																										
Ford	Transit	2.4L DIESEL	2006.5	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	TBM(Tracking And Blocking Module)																										
Ford	Transit	2.5L DIESEL	SYSTEM SEARCH																											
Ford	Transit	2.5L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	ASM(Auto Shift Manual)																											
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																										
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Transit	2.5L DIESEL	RCM(Restraint Control Module)																											
Ford	Transit	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Transit	2.5L DIESEL	CSM(Central Security Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	RIM(Remote Immobilizer Module)																											
Ford	Transit	2.5L DIESEL	ACM(Audio Control Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)												V														
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)						V																				
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Transit	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Transit	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Transit	3.7L	TiVCT	ABS(Anti-Lock Brake System)												V														
Ford	Transit	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Transit	3.7L	TiVCT	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.7L	TiVCT	BCM(Body Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Ford	Transit	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Transit	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.7L	TiVCT	IPM-A(Image Processing Module A)							V																			
Ford	Transit	3.7L	TiVCT	IPM-B(Image Processing Module B)																										
Ford	Transit	3.7L	TiVCT	PAM(Park Aid Module)																										
Ford	Transit	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Transit	3.7L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.7L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.7L	TiVCT	TRM(Trailer Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Thunderbird	3.9L	4V	SYSTEM SEARCH																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ACM(Audio Control Module)																										
Ford	Thunderbird	3.9L	4V	DDM(Driver's Door Module)																										
Ford	Thunderbird	3.9L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Thunderbird	3.9L	4V	GEM(Generic Electronic Module)																										
Ford	Thunderbird	3.9L	4V	HEC(Hybrid Electrical Cluster)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	REM(Rear Electronic Module)																										
Lincoln	Aviator	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Aviator	4.6L	4V	PCM(Powertrain Control Module)																										
Lincoln	Aviator	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Aviator	4.6L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Aviator	4.6L	4V	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	Aviator	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Aviator	4.6L	4V	IC(Instrument Cluster)																										
Lincoln	Aviator	4.6L	4V	PAM(Parking Aid Module)																										
Lincoln	Aviator	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Aviator	4.6L	4V	TPM(Tire Pressure Monitor)																										
Lincoln	Aviator	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Lincoln	Aviator	4.6L	4V	VSM(Vehicle Security Module)																										
Lincoln	Continental	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Continental	4.6L	4V	PCM(PowerTrain Control Module)																										
Lincoln	Continental	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Continental	4.6L	4V	ACM(Audio Control Module)																										
Lincoln	Continental	4.6L	4V	CPM(Cellular Phone Module)																										
Lincoln	Continental	4.6L	4V	DDM(Driver's Door Module)																										
Lincoln	Continental	4.6L	4V	DSM(Driver's Seat Module)																										
Lincoln	Continental	4.6L	4V	LCM(Lighting Control Module)																										
Lincoln	Continental	4.6L	4V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Continental	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Continental	4.6L	4V	VDM(Vehicle Dynamic Module)																										
Lincoln	Continental	4.6L	4V	VIC(Virtual Image Cluster)																										
Lincoln	Continental	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Continental	4.6L	4V	PATS(Passive Anti Theft System)																										
Lincoln	LS	ALL	SYSTEM SEARCH																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	ABS(Anti-Lock Brake System)																											
Lincoln	LS	ALL	DCSM(Driver-Dual Climate Control Seat Module)																											
Lincoln	LS	ALL	DDM(Driver's Door Module)																											
Lincoln	LS	ALL	DSM(Driver's Seat Module)																											
Lincoln	LS	ALL	EPB(Electronic Parking Brake)																											
Lincoln	LS	ALL	PAM(Parking Aid Module)																											
Lincoln	LS	ALL	RCM(Restraint Control Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	SCLM(Steering Column Locking Module)																											
Lincoln	LS	ALL	EATC(Electronic Automatic Temperature Control)																											
Lincoln	LS	ALL	GEM(Generic Electronic Module)																											
Lincoln	LS	ALL	HEC(Hybrid Electrical Cluster)																											
Lincoln	LS	ALL	PCSM(Passenger Climate Control Seat Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	MKS	3.7L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKS	3.7L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Lincoln	MKS	3.7L	4V	2009	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.7L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2009	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2009	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2009	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2010 ~	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2010 ~	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Lincoln	MKS	3.7L	4V	2010 ~	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	MKS	3.7L	4V	2010 ~	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2010 ~	HUD(Head Up Display)																									
Lincoln	MKS	3.7L	4V	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2010 ~	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKX	3.5L	4V	2007	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2007	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2007	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2007	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Lincoln	MKX	3.5L	4V	2007	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2007	EATC(Electronic Automatic Temperature Control)																									
Lincoln	MKX	3.5L	4V	2007	GEM(Generic Electronic Module)																									
Lincoln	MKX	3.5L	4V	2007	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2007	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2007	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2007	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2007	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2007	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2007	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2007	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2007	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2008	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2008	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2008	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2008	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2008	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Lincoln	MKX	3.5L	4V	2008	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2008	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	MKX	3.5L	4V	2008	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2008	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2008	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2008	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2008	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2008	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2008	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2008	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2008	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Lincoln	MKX	3.5L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2009	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2009	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2009	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2009	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2009	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2010	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2010	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2010	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	MKX	3.5L	4V	2010	DCSM(Driver-Dual Climate Control Seat Module)				V																					
Lincoln	MKX	3.5L	4V	2010	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2010	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2010	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2010	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2010	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2010	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2010	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2010	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKZ	3.0L	2006	SYSTEM SEARCH																										
Lincoln	MKZ	3.0L	2006	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.0L	2006	ABS(Anti-Lock Brake System)													V													
Lincoln	MKZ	3.0L	2006	ACM(Audio Control Module)																										
Lincoln	MKZ	3.0L	2006	DCSM(Driver-Dual Climate Control Seat Module)				V																						
Lincoln	MKZ	3.0L	2006	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.0L	2006	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.0L	2006	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.0L	2006	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.0L	2006	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.0L	2006	IC(Instrument Cluster)																										
Lincoln	MKZ	3.0L	2006	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.0L	2006	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.0L	2006	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2007	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2007	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2007	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2007	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2007	DCSM(Driver-Dual Climate Control Seat Module)				V																						
Lincoln	MKZ	3.5L	2007	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2007	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	MKZ	3.5L	2007	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2007	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.5L	2007	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.5L	2007	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2007	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2007	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2007	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2007	PATS(Passive Anti Theft System)		V																								
Lincoln	MKZ	3.5L	2008	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2008	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2008	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2008	ABS(Anti-Lock Brake System)													V													
Lincoln	MKZ	3.5L	2008	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2008	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2008	DCSM(Driver-Dual Climate Control Seat Module)					V																					
Lincoln	MKZ	3.5L	2008	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2008	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2008	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2008	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2008	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2008	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2008	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2008	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2008	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2009	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2009	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2009	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2009	ABS(Anti-Lock Brake System)													V													
Lincoln	MKZ	3.5L	2009	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2009	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2009	DCSM(Driver-Dual Climate Control Seat Module)					V																					
Lincoln	MKZ	3.5L	2009	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2009	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	MKZ	3.5L	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2009	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2009	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2009	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2009	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2009	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2009	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2009	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2010	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2010	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2010	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2010	ABS(Anti-Lock Brake System)													V													
Lincoln	MKZ	3.5L	2010	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2010	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2010	DCSM(Driver-Dual Climate Control Seat Module)					V																					
Lincoln	MKZ	3.5L	2010	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2010	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	3.5L	2010	FDIM(Front Display Interface Module)																										
Lincoln	MKZ	3.5L	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2010	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	3.5L	2010	HCM(Headlamp Control Module)																										
Lincoln	MKZ	3.5L	2010	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2010	ILCM(Interior Lighting Control Module)																										
Lincoln	MKZ	3.5L	2010	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	3.5L	2010	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2010	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2010	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2010	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	3.5L	2010	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	3.5L	2010	TCM(Transmission Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)												V														
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)						V																				
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRCM(Transmission Range Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)												V														
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM(Body Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A(Image Processing Module A)						V																				
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM(Transmission Range Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Lincoln	Navigator	2007 ~	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)				V																						
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	APIM(Accessory Protocol Interface Module)																										
Lincoln	Navigator	2007 ~	5.4L	DCSM(Driver-Dual Climate Control Seat Module)					V																					
Lincoln	Navigator	2007 ~	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GPSM(Global Positioning System Module)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	2007 ~	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	2007 ~	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	2007 ~	5.4L	PRB(Power Running Board)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCU(Audio Rear Control Unit)																										
Lincoln	Navigator	2007 ~	5.4L	RETM(Rear Entertainment Module)																										
Lincoln	Navigator	2007 ~	5.4L	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	Navigator	2007 ~	5.4L	TCCM(Transfer Case Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	TCM(Transmission Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	2007 ~	5.4L	4X4(4x4 Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PATS(Passive Anti Theft System)										V	V															
Lincoln	Navigator	~ 2007	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	DCSM(Driver-Dual Climate Control Seat Module)					V																					
Lincoln	Navigator	~ 2007	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	GEM(Generic Electronic Module)																										
Lincoln	Navigator	~ 2007	5.4L	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Navigator	~ 2007	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	~ 2007	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	~ 2007	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	~ 2007	5.4L	RIM(Remote Immobilizer Module)																										
Lincoln	Navigator	~ 2007	5.4L	VSM(Vehicle Security Module)																										
Lincoln	Town Car	4.6L	2V	SYSTEM SEARCH																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)				V																						
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)								V																		
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	LCM(Lighting Control Module)																										
Lincoln	Town Car	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Lincoln	Town Car	4.6L	2V	DDM(Driver's Door Module)																										
Lincoln	Town Car	4.6L	2V	DSM(Driver's Seat Module)																										
Lincoln	Town Car	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Town Car	4.6L	2V	RATC(Rear Air Temperature Control)																										
Lincoln	Town Car	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Lincoln	Town Car	4.6L	2V	PAM(Parking Aid Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	HEC(Hybrid Electrical Cluster)																										
Lincoln	Town Car	4.6L	2V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Town Car	4.6L	2V	RASM(Rear Air Suspension Module)																										
Mercury	Grand Marquis	4.6L	2V	SYSTEM SEARCH																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	DDM(Driver's Door Module)																										
Mercury	Grand Marquis	4.6L	2V	IC(Instrument Cluster)																										
Mercury	Grand Marquis	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Grand Marquis	4.6L	2V	LCM(Lighting Control Module)																										
Mercury	Grand Marquis	4.6L	2V	MC(Message Center)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RIM(Remote Immobilizer Module)																										
Mercury	Grand Marquis	4.6L	2V	GEM(Generic Electronic Module)																										
Mercury	Grand Marquis	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Mercury	Marauder	4.6L	4V	SYSTEM SEARCH																										
Mercury	Marauder	4.6L	4V	PCM(Powertrain Control Module)																										
Mercury	Marauder	4.6L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Marauder	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Marauder	4.6L	4V	RASM(Rear Air Suspension Module)																										
Mercury	Marauder	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Mercury	Marauder	4.6L	4V	DDM(Driver's Door Module)																										
Mercury	Marauder	4.6L	4V	LCM(Lighting Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	Milan	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)								V																		
Mercury	Milan	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SYSTEM SEARCH																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Milan	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	Milan	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)										V	V															
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Milan	3.0L	4V	PSCM(Power Steering Control Module)								V																		
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	Milan	3.0L	4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Milan	3.0L	4V	PATS(Passive Anti Theft System)		V																								
Mercury	Montego	3.0L	4V	SYSTEM SEARCH																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Montego	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Montego	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Montego	3.0L	4V	DSM(Driver's Seat Module)																										
Mercury	Montego	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Montego	3.0L	4V	GEM(Generic Electronic Module)																										
Mercury	Montego	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Montego	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Montego	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Montego	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Mercury	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Mercury	Mountaineer	2010 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	TCM(Transmission Control Module)			V																							
Mercury	Mountaineer	2010 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2010 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2010 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2010 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2010 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2010 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.6L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	Mountaineer	2009 MY	4.6L	TCM(Transmission Control Module)			V																							
Mercury	Mountaineer	2009 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2009 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2009 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2009 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2009 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	TCM(Transmission Control Module)			V																							
Mercury	Mountaineer	2008 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2008 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2008 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2008 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2008 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	TCM(Transmission Control Module)			V																							
Mercury	Mountaineer	2007 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	Mountaineer	2007 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2007 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2007 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2007 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2007 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	TCM(Transmission Control Module)			V																							
Mercury	Mountaineer	2006 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2006 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2006 MY	4.6L	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	Mountaineer	2006 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2006 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2006 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2006 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2006 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2003 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2003 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2003 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2003 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2003 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2003 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2003 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2002 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2002 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2002 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2002 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	Mountaineer	2002 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2002 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2001 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2001 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2001 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2001 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2001 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2001 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2000 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2000 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2000 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2000 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2000 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2000 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	1999 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1999 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1999 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1999 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1999 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1999 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	1998 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1998 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1998 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1998 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1998 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1997 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1997 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1997 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1997 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1997 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)		V																								
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	PATS Function	Reset KAM_TCM	MAF Sensor Contamination Test	DCSM Module Installation-Test	DSP Module Installation	LDWS Camera Alignment	PSCM Module Installation	IC Installation-Test	Program additional ignition key	Ignition key code erase	IVD Initialization Sequence	ABS Installation	LIN New Module Initialization-Test	RVC Configuration-Test	Erase One Remote Transmitter	Erase All Remote Transmitter	Injector electrical test	Engine running test	Injector contribution test	Yaw Rate Sensor	DPF Reset	Clear EGR Adaptive Tables	Clear Fuel Injector/HP Pump Adaptive Tables	Water In Fuel Reset	DPF Manual Regeneration
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)		V																								
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)		V																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Vehicle Info.	Vehicle Info.	Vehicle Info.																												
Ford	Crown Victoria	4.6L	2V	SYSTEM SEARCH																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	DDM(Driver's Door Module)																										
Ford	Crown Victoria	4.6L	2V	IC(Instrument Cluster)																										
Ford	Crown Victoria	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Crown Victoria	4.6L	2V	LCM(Lighting Control Module)																										
Ford	Crown Victoria	4.6L	2V	MC(Message Center)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	Crown Victoria	4.6L	2V	GEM(Generic Electronic Module)																										
Ford	Crown Victoria	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.4L	DIESEL	SYSTEM SEARCH																										
Ford	Ecosport	1.4L	DIESEL	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.4L	DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.4L	DIESEL	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.4L	DIESEL	IC(Instrument Cluster)																										
Ford	Ecosport	1.4L	DIESEL	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	FFV	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Ecosport	1.6L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	FFV	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Escort	2.0L	SYSTEM SEARCH																											
Ford	Escort	2.0L	PCM(PowerTrain Control Module)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ECS(Electronic Crash Sensor)																											
Ford	Escort	2.0L	PATS(Passive Anti Theft System)																											
Ford	Escort	2.0L	RAP(Remote Anti-Theft/Personality Module)																											
Ford	Edge	3.5L	4V	SYSTEM SEARCH																										
Ford	Edge	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Edge	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Edge	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Edge	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	4V	IC(Instrument Cluster)																										
Ford	Edge	3.5L	4V	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Edge	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Edge	3.5L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Edge	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.5L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.5L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	TiVCT	RFA(Remote Function Actuator)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Edge	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.5L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.5L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Edge	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.7L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.7L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.7L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.7L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.7L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.7L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Edge	3.7L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.7L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.7L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.7L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.7L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.7L	TiVCT	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.7L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Escape	Up to 2004	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Escape	Up to 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	Up to 2004	Immobilizer																											
Ford	Escape	Up to 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	Up to 2004	RCM(Restraint Control Module)																											
Ford	Escape	Up to 2004	GEM(Generic Electronic Module)																											
Ford	Escape	From 2004	SYSTEM SEARCH																											
Ford	Escape	From 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	From 2004	PATS(Passive Anti Theft System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	RCM(Restraint Control Module)																											
Ford	Escape	From 2004	IC(Instrument cluster)																											
Ford	Escape	From 2004	GEM(Generic Electronic Module)																											
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Excursion	GASOLINE	SYSTEM SEARCH																											
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											
Ford	Excursion	GASOLINE	ABS(Anti-Lock Brake System)																											
Ford	Excursion	GASOLINE	CSM(Central Security Module)																											
Ford	Excursion	GASOLINE	DSM(Driver's Seat Module)																											
Ford	Excursion	GASOLINE	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	GASOLINE	ECS(Electronic Crash Sensor)																											
Ford	Excursion	GASOLINE	GEM(Generic Electronic Module)																											
Ford	Excursion	GASOLINE	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	GASOLINE	OTC(Overhead Trip Computer)																											
Ford	Excursion	GASOLINE	PAM(Parking Aid Module)																											
Ford	Excursion	GASOLINE	PATS(Passive Anti Theft System)																											
Ford	Excursion	GASOLINE	TCM(Transmission Control Module)																											
Ford	Excursion	GASOLINE	VSM(Vehicle Security Module)																											
Ford	Excursion	DIESEL	SYSTEM SEARCH																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Excursion	DIESEL	CSM(Central Security Module)																											
Ford	Excursion	DIESEL	DSM(Driver's Seat Module)																											
Ford	Excursion	DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	DIESEL	ECS(Electronic Crash Sensor)																											
Ford	Excursion	DIESEL	GEM(Generic Electronic Module)																											
Ford	Excursion	DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	DIESEL	OTC(Overhead Trip Computer)																											
Ford	Excursion	DIESEL	PAM(Parking Aid Module)																											
Ford	Excursion	DIESEL	PATS(Passive Anti Theft System)																											
Ford	Excursion	DIESEL	TCM(Transmission Control Module)																											
Ford	Excursion	DIESEL	VSM(Vehicle Security Module)																											
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	EATC(Electronic Automatic Temperature Control)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VSM(Vehicle Security Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TBC(Trailer Brake Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCCM(Transfer Case Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	GEM(Generic Electronic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	5.4L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VSM(Vehicle Security Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	APIM(Accessory Protocol Interface Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GPSM(Global Positioning System Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	4.6L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PRB(Power Running Board)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCU(Audio Rear Control Unit)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RETM(Rear Entertainment Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	TCM(Transmission Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	4X4(4x4 Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VSM(Vehicle Security Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2015 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2014 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PATS(Passive Anti Theft System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Caliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2012 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Caliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2010 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2009 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2005 MY	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2005 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2005 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2005 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2005 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2005 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2004 MY	SYSTEM SEARCH																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2004 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2004 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2004 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2004 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2004 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2003 MY	SYSTEM SEARCH																											
Ford	Explorer	2003 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2003 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2003 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2003 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2003 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2003 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2003 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2002 MY	SYSTEM SEARCH																											
Ford	Explorer	2002 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2002 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2002 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2002 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2002 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2002 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2002 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2001 MY	SYSTEM SEARCH																											
Ford	Explorer	2001 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2001 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2001 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2001 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer	2001 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2001 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	SYSTEM SEARCH																											
Ford	Explorer	2000 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2000 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2000 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	2000 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2000 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	1999 MY	SYSTEM SEARCH																											
Ford	Explorer	1999 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1999 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1999 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1999 MY	PAM(Parking Aid Module)																											
Ford	Explorer	1998 MY	SYSTEM SEARCH																											
Ford	Explorer	1998 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1998 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1998 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1998 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1997 MY	SYSTEM SEARCH																											
Ford	Explorer	1997 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1997 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1997 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1997 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer SportTrac	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer SportTrac	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer SportTrac	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2004 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	RAP(Remote Anti-Theft/Personality Module)																									
Ford	E-Series	5.4L	2V	2004 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2004 ~	VSM(Vehicle Security Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2009 ~	ACM(Audio Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	E-Series	5.4L	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	E-Series	5.4L	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	E-Series	5.4L	2V	2009 ~	IPC(Instrument Panel Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																										
Ford	F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																										
Ford	F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																									
Ford	F150	4.6L(BETA)	3V	SYSTEM SEARCH																										
Ford	F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																										
Ford	F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																										
Ford	F150	4.6L(BETA)	3V	ACM(Audio Control Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																										
Ford	F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																										
Ford	F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																										
Ford	F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	4.6L(BETA)	3V	IC(Instrument Cluster)																										
Ford	F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																										
Ford	F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																										
Ford	F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																										
Ford	F150	4.6L(BETA)	3V	PRB(Power Running Board)																										
Ford	F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																										
Ford	F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																										
Ford	F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																										
Ford	F150	5.0L	TiVCT	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	F150	5.0L	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	5.0L	TiVCT	ACM(Audio Control Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	5.0L	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	5.0L	TiVCT	IC(Instrument Cluster)																										
Ford	F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PRB(Power Running Board)																										
Ford	F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	5.0L	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	5.0L	TiVCT	TCM(Transmission Control Module)																										
Ford	F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	F150	5.4L	3V	2009 ~	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2009 ~	PRB(Power Running Board)																									
Ford	F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	6.2L(BETA)	2V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																										
Ford	F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																										
Ford	F150	6.2L(BETA)	2V	ACM(Audio Control Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																										
Ford	F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																										
Ford	F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																										
Ford	F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																										
Ford	F150	6.2L(BETA)	2V	IC(Instrument Cluster)																										
Ford	F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																										
Ford	F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																										
Ford	F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																										
Ford	F150	6.2L(BETA)	2V	PRB(Power Running Board)																										
Ford	F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																										
Ford	F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																										
Ford	F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																										
Ford	F150	Other	2004 ~ 2008	SYSTEM SEARCH																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																										
Ford	F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																										
Ford	F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																										
Ford	F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	Other	2004 ~ 2008	IC(Instrument Cluster)																										
Ford	F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										
Ford	F250	7.3L	SYSTEM SEARCH																											
Ford	F250	7.3L	PCM(PowerTrain Control Module)																											
Ford	F250	7.3L	ABS(Anti-Lock Brake System)																											
Ford	F250	7.3L	ECS(Electronic Crash Sensor)																											
Ford	F250	7.3L	GEM(Generic Electronic Module)																											
Ford	F250	6.2L	SYSTEM SEARCH																											
Ford	F250	6.2L	PCM(Powertrain Control Module)																											
Ford	F250	6.2L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.2L	ACM(Audio Control Module)																											
Ford	F250	6.2L	APIM(Accessory Protocol Control Module)																											
Ford	F250	6.2L	BCMii(Body Control Module)																											
Ford	F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																											
Ford	F250	6.2L	DSM(Driver Seat Module)																											
Ford	F250	6.2L	GPSM(Global Positioning System Module)																											
Ford	F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F250	6.2L	IPC(Instrument Panel Control Module)																											
Ford	F250	6.2L	PAM(Parking Aid Module)																											
Ford	F250	6.2L	RCM(Restraint Control Module)																											
Ford	F250	6.2L	SCCM(Streering Colume Control Module)																											
Ford	F250	6.2L	TBC(Trailer Brake Control Module)																											
Ford	F250	6.2L	TCCM(Transfer Case Control Module)																											
Ford	F250	6.2L	TPM(Tire Pressure Monitor)																											
Ford	F250	6.0L	SYSTEM SEARCH																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.0L	GEM(Generic Electronic Module)																											
Ford	F250	6.0L	HEC(Hybrid Electrical Cluster)																											
Ford	F250	6.0L	OTC(Overhead Trip Computer)																											
Ford	F250	6.0L	PAM(Parking Aid Module)																											
Ford	F250	6.0L	PATS(Passive Anti Theft System)																											
Ford	F250	6.0L	RCM(Restraint Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	VSM(Vehicle Security Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Caliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SYSTEM SEARCH																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM(PowerTrain Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4(4x4 Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS(Anti-Lock Brake System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM(Audio Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM(Auxiliary Heater Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM(Accessory Protocol Interface Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM(Circuit Deactivation Ignition Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM(Driver's Seat Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GPSM(Global Positioning System Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC(Instrument Cluster)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM(Parking Aid Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM(Restraint Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM(Rear Entertainment Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS(Satellite Digital Audio Receiver System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC(Trailer Brake Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM(Transmission Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)	V	V	V	V	V	V	V	V	V																
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)										V															
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)	V	V	V	V	V	V	V	V	V																
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																									
Ford	Fiesta	1.4L	DURATEC 16V	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)												V	V													
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)														V												
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)															V											
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																V	V	V	V	V	V	V	V	V	V	V
Ford	Fiesta	1.4L	DURATEC 16V	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)													V													
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Fiesta	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)												V	V													
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)														V												
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)															V											
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																V	V	V	V	V	V	V	V	V	V	V
Ford	Fiesta	1.6L	DURATEC	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	BCMii(Body Control Module)																										
Ford	Fiesta	1.6L	DURATEC	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	BCM(Body Control Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Fiesta	1.6L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.6L	TiVCT	VSM(Vehicle Security Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	Zetec Rocam	IC(Instrument Cluster)																										
Ford	Fiesta	1.6L	Zetec Rocam	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	RKE(Remote Keyless Entry)																										
Ford	Fiesta	1.6L	Zetec Rocam	TCM(Transmission Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	SYSTEM SEARCH																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																										
Ford	Fiesta	2.0L	SYSTEM SEARCH																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)													V	V													
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																	V	V	V	V	V	V	V	V	V	V	V
Ford	Fiesta	2.0L	ACM(Audio Control Module)																											
Ford	Fiesta	2.0L	EATC(Electronic Automatic Temperature Control)																											
Ford	Fiesta	2.0L	GEM(Generic Electronic Module)																											
Ford	Fiesta	2.0L	IC(Instrument Cluster)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	RCM(Restraint Control Module)																											
Ford	Fiesta	2.0L	PATS(Passive Anti Theft System)-BETA																											
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Focus	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	ZETEC ROCAM	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Focus	1.6L	ZETEC ROCAM	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)													V													
Ford	Focus	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																	V	V			V	V	V	V	V	V
Ford	Focus	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Focus	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic power steering)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ACM(Audio control module)																										
Ford	Focus	1.8L	DURATEC HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.8L	DURATEC HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.8L	DURATEC HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.8L	DURATEC HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.8L	DURATEC HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	IC(Instrument cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	NAV(Navigation System)																										
Ford	Focus	1.8L	DURATEC HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	MC(Message Center)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FDIM(Front Display Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TCM(Transmission control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CSM(Central Security Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EPS(Electronic power steering)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GDM(Generic Display Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	NAV(Navigation System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RKE(Remote Keyless Entry)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TBM(Tracking And Blocking Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SRM(Speech recognition module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SYSTEM SEARCH																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ACM(Audio Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	BCM(Body Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DDM(Driver's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	IPC(Instrument Panel Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PAM(Parking Aid Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PSCM(Power Steering Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SASM(Steering Angle Sensor Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Focus	2.0L DIESEL	2003 ~ 2008	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FACM(Fuel Additive Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RETM(Rear Entertainment Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RKE(Remote Keyless Entry)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	TCM(Transmission control module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	DDM(Driver's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	MC(Message Center)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ACM(Audio control module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																	V	V								
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)													V													
Ford	Focus C-MAX	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																	V	V			V	V	V	V	V	V
Ford	Focus C-MAX	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Focus C-MAX	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Flex	3.5L	4V	SYSTEM SEARCH																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	4V	ACM(Audio control module)																										
Ford	Flex	3.5L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	4V	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	4V	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	4V	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	4V	IC(Instrument cluster)																										
Ford	Flex	3.5L	4V	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	4V	LTM(Liftgate/Trunk Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Flex	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	4V	Factory Keyless Entry Code																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio control module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC(Instrument cluster)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Flex	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	TiVCT	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Flex	3.5L	TiVCT	ACM(Audio control module)																										
Ford	Flex	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	TiVCT	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	TiVCT	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	TiVCT	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	TiVCT	IC(Instrument cluster)																										
Ford	Flex	3.5L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	TiVCT	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Ford	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Ford	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Ford	Freestyle	3.0L	4V	SYSTEM SEARCH																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Freestyle	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Freestyle	3.0L	4V	ACM(Audio Control Module)																										
Ford	Freestyle	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Freestyle	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Freestyle	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Freestyle	3.0L	4V	IC(Instrument Cluster)																										
Ford	Freestyle	3.0L	4V	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Freestyle	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Freestyle	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Five Hundred	3.0L	4V	SYSTEM SEARCH																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Five Hundred	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Five Hundred	3.0L	4V	ACM(Audio Control Module)																										
Ford	Five Hundred	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Five Hundred	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Five Hundred	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Five Hundred	3.0L	4V	IC(Instrument Cluster)																										
Ford	Five Hundred	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Five Hundred	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Five Hundred	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Ford GT	5.4L	4V	SYSTEM SEARCH																										
Ford	Ford GT	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	IC(Instrument Cluster)																										
Ford	Ford GT	5.4L	4V	PATS(Passive Anti Theft System)																										
Ford	Ford GT	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	TCM(Transmission control module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Fusion	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	DURATEC	IC(Instrument cluster)																										
Ford	Fusion	1.6L	DURATEC	ACM(Audio control module)																										
Ford	Fusion	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fusion	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SYSTEM SEARCH																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BCM(Body Control Module)											V															
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HUD(Head Up Display)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM(Secondary OBD Control Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	TCU(Telematic Control Unit Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Fusion	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.5L	IVCT	SYSTEM SEARCH																										
Ford	Fusion	2.5L	IVCT	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	IVCT	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	IVCT	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	IVCT	BCM(Body Control Module)										V																
Ford	Fusion	2.5L	IVCT	C-CM(Cruise Control Module)																										
Ford	Fusion	2.5L	IVCT	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.5L	IVCT	DDM(Driver's Door Module)																										
Ford	Fusion	2.5L	IVCT	DSM(Driver's Seat Module)																										
Ford	Fusion	2.5L	IVCT	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	IVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.5L	IVCT	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	IVCT	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	IVCT	GWM(Gateway Module A)																										
Ford	Fusion	2.5L	IVCT	HUD(Head Up Display)																										
Ford	Fusion	2.5L	IVCT	IPC(Instrument Panel Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Fusion	2.5L	IVCT	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.5L	IVCT	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	IVCT	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	IVCT	PDM(Passenger's Door Module)																										
Ford	Fusion	2.5L	IVCT	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	IVCT	RACM(Rear Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	IVCT	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.5L	IVCT	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.5L	IVCT	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.5L	IVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	IVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.0L	4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Fusion	3.5L	4V	SYSTEM SEARCH																										
Ford	Fusion	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.5L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.5L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.5L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.5L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.5L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	KA	2000 MY	SYSTEM SEARCH																											
Ford	KA	2000 MY	PCM(PowerTrain Control Module)																											
Ford	KA	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	KA	2000 MY	RCM(Restraint Control Module)																											
Ford	KA	1999 MY	PCM(PowerTrain Control Module)																											
Ford	KA	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Kuga	2.0L DIESEL	SYSTEM SEARCH																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)														V													
Ford	Kuga	2.0L DIESEL	TCM(Transmission Control Module)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																											
Ford	Kuga	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																											
Ford	Kuga	2.0L DIESEL	AWD(All Wheel Drive Module)																											
Ford	Kuga	2.0L DIESEL	BCMii(Body Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Kuga	2.0L DIESEL	CCMii(Cruise Control Module)																											
Ford	Kuga	2.0L DIESEL	CMR(Camera Module Rear)																											
Ford	Kuga	2.0L DIESEL	D_DCU(Driver Door Control Unit)																											
Ford	Kuga	2.0L DIESEL	DDM(Driver's Door Module)																											
Ford	Kuga	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Kuga	2.0L DIESEL	EPS(Electronic Power Steering)																											
Ford	Kuga	2.0L DIESEL	FDSM(Front Distance Sensing Module)																											
Ford	Kuga	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																											
Ford	Kuga	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Kuga	2.0L DIESEL	GEM(Generic Electronic Module)																											
Ford	Kuga	2.0L DIESEL	GPSM(Global Positioning System Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Kuga	2.0L DIESEL	IPM-A(Image Processing Module A)																											
Ford	Kuga	2.0L DIESEL	IPM-B(Image Processing Module B)																											
Ford	Kuga	2.0L DIESEL	IPC(Instrument Panel Control Module)																											
Ford	Kuga	2.0L DIESEL	IC(Instrument Cluster)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PSCM(Power Steering Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RFA(Remote Function Actuator)																											
Ford	Kuga	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																											
Ford	Kuga	2.0L DIESEL	RETM(Rear Entertainment Module)																											
Ford	Kuga	2.0L DIESEL	SASM(Steering Angle Sensor Module)																											
Ford	Kuga	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Kuga	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Kuga	2.0L DIESEL	SRM(Speech Recognition Module)																											
Ford	Kuga	2.0L DIESEL	TRM(Trailer Module)																											
Ford	Kuga	2.5L	I5	SYSTEM SEARCH																										
Ford	Kuga	2.5L	I5	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.5L	I5	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.5L	I5	ACM(Audio Control Module)																										
Ford	Kuga	2.5L	I5	AWD(All Wheel Drive Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Kuga	2.5L	I5	CMR(Camera Module Rear)																										
Ford	Kuga	2.5L	I5	D_DCU(Driver Door Control Unit)																										
Ford	Kuga	2.5L	I5	EATC(Electronic Automatic Temperature Control)																										
Ford	Kuga	2.5L	I5	EPS(Electronic Power Steering)																										
Ford	Kuga	2.5L	I5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Kuga	2.5L	I5	GEM(Generic Electronic Module)																										
Ford	Kuga	2.5L	I5	HCM(Headlamp Control Module)																										
Ford	Kuga	2.5L	I5	IC(Instrument Cluster)																										
Ford	Kuga	2.5L	I5	PAM(Parking Aid Module)																										
Ford	Kuga	2.5L	I5	PDM(Passenger's Door Module)																										
Ford	Kuga	2.5L	I5	RCM(Restraint Control Module)																										
Ford	Kuga	2.5L	I5	RETM(Rear Entertainment Module)																										
Ford	Kuga	2.5L	I5	RKE(Remote Keyless Entry)																										
Ford	Kuga	2.5L	I5	SRM(Speech Recognition Module)																										
Ford	Kuga	2.5L	I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																V	V				V	V	V	V	V	V
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Mondeo	2010 MY	2.5L I5	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.5L I5	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.5L I5	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.5L I5	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.5L I5	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.5L I5	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.5L I5	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.5L I5	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SYSTEM SEARCH																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																V	V									
Ford	Mondeo	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	ABS(Anti-Lock Brake System)																V	V									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	AHCM(Auxiliary Heater Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	BCMii(Body Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CCMii(Cruise Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DDM(Driver's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DSM(Driver's Seat Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HCM(HeadLamp Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RFA(Remote Function Actuator)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TRM(Trailer Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ACM(Audio Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	CDP(Compact Disc Player)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GDM(Generic Display Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	NAV(Navigation System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SRM(Speech Recognition Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	SYSTEM SEARCH																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	GEM(Generic Electronic Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	HCM(Headlamp Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2000 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	2000 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	2000 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1999 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1999 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Mondeo	1998 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1998 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1998 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1997 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1997 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1997 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1997 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	BCM-B(Body Control Module B)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Mustang	3.7L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Mustang	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Mustang	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Mustang	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Mustang	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Mustang	3.7L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.8L	SYSTEM SEARCH																											
Ford	Mustang	3.8L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.8L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.8L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.8L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.8L	RCM(Restraint Control Module)																											
Ford	Mustang	3.9L	SYSTEM SEARCH																											
Ford	Mustang	3.9L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.9L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.9L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.9L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.9L	RCM(Restraint Control Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	BCM-B(Body Control Module B)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.0L	V6 (SOHC)	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.0L	V6 (SOHC)	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Mustang	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Mustang	4.0L	V6 (SOHC)	PAM(Parking Aid Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PSCM(Power Steering Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Mustang	4.0L	V6 (SOHC)	PATS(Passive Anti Theft System)-BETA																										
Ford	Mustang	4.6L	3V	SYSTEM SEARCH																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	BCM-B(Body Control Module B)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	PATS(Passive Anti Theft System)-BETA																										
Ford	Mustang	5.0L	~ 2014	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FDIM(Front Display Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM(Body Control Module)										V															
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	C-CM(Cruise Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DACM-C(Digital Audio Control Module C)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DDM(Driver's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSM(Driver's Seat Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GWM(Gateway Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	HUD(Head Up Display)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ICM(Information Center Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-A(Movable Roof Control Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-B(Movable Roof Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PAM(Parking Aid Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PDM(Passenger's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Caliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Mustang	5.0L	2015 ~	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	RTM(Radio Transceiver Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCM-E(Seat Control Module E)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Mustang	5.4L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	BCM-B(Body Control Module B)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.4L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.4L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.4L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.4L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.4L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.4L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	BCM-B(Body Control Module B)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.8L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.8L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.8L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.8L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.8L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.8L	4V	PAM(Parking Aid Module)																										
Ford	Mustang	5.8L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)											V															
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM-B(Body Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ICM(Information Center Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-A(Movable Roof Control Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-B(Movable Roof Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Diesel(WL-CD)	SYSTEM SEARCH																											
Ford	Ranger	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.0 Diesel(WE-CD)	SYSTEM SEARCH																											
Ford	Ranger	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Ranger	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Gasoline	SYSTEM SEARCH																											
Ford	Ranger	2.5 Gasoline	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Gasoline	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Gasoline	ACM(Audio Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Ranger	2.5 Gasoline	BCMii(Body Control Module)																											
Ford	Ranger	2.5 Gasoline	DDM(Driver's Door Module)																											
Ford	Ranger	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																											
Ford	Ranger	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Ranger	2.5 Gasoline	IPC(Instrument Panel Control Module)																											
Ford	Ranger	2.5 Gasoline	PAM(Parking Aid Module)																											
Ford	Ranger	2.5 Gasoline	PDM(Passenger's Door Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	SRM(Speech Recognition Module)																											
Ford	Ranger	2.5 Gasoline	TBM(Tracking And Blocking Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TRM(Trailer Module)																											
Ford	Ranger	2.5 Gasoline	PATS(Passive Anti Theft System)-BETA																											
Ford	Ranger	3.0L	Other	SYSTEM SEARCH																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	Other	IC(Instrument Cluster)																										
Ford	Ranger	3.0L	Other	OCSM(Occupant Classification System Module)																										
Ford	Ranger	3.0L	Other	4X4(4x4 Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	3.0L	FFV	SYSTEM SEARCH																										
Ford	Ranger	3.0L	FFV	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	FFV	PATS(Passive Anti Theft System)																										
Ford	Ranger	3.0L	FFV	RAP(Remote Anti-Theft/Personality Module)																										
Ford	Ranger	3.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Ranger	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Ranger	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Ranger	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Ranger	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	4X4(4x4 Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	IC(Instrument Cluster)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	LTM(Liftgate/Trunk Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SECM(Steering Effort Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Caliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HUD(Head Up Display)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	BCM(Body Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Taurus	3.5L	TiVCT	2013 ~	GFM(Generic Function Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RACM(Rear Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SCCM(Steering Column Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.0L	2000 ~	SYSTEM SEARCH																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	2000 ~	EATC(Electronic Automatic Temperature Control)																										
Ford	Taurus	3.0L	2000 ~	GEM(Generic Electronic Module)																										
Ford	Taurus	3.0L	2000 ~	IC(Instrument Cluster)																										
Ford	Taurus	3.0L	2000 ~	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	SYSTEM SEARCH																										
Ford	Taurus	3.0L	~ 1999	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	~ 1999	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	~ 1999	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	RIM(Remote Immobilizer Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SYSTEM SEARCH																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PCM(PowerTrain Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ABS(Anti-Lock Brake System)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ACM(Audio Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	GEM(Generic Electronic Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	IC(Instrument Cluster)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PAM(Parking Aid Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	RCM(Restraint Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SRM(Speech Recognition Module)																										
Ford	Transit	2.0L	2001 ~ 2004	SYSTEM SEARCH																										
Ford	Transit	2.0L	2001 ~ 2004	PCM(PowerTrain Control Module)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																				V						
Ford	Transit	2.0L	2001 ~ 2004	ASM(Auto Shift Manual)																										
Ford	Transit	2.0L	2001 ~ 2004	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.0L	2001 ~ 2004	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																				V						
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																				V						
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																				V						
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																				V						
Ford	Transit	2.4L DIESEL	2004 ~ 2006	CSM(Central Security Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2006.5	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2006.5	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	2.4L DIESEL	2006.5	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	PAM(Parking Aid Module)																										
Ford	Transit	2.4L DIESEL	2006.5	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	TBM(Tracking And Blocking Module)																										
Ford	Transit	2.5L DIESEL	SYSTEM SEARCH																											
Ford	Transit	2.5L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																					V						
Ford	Transit	2.5L DIESEL	ASM(Auto Shift Manual)																											
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																										
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Transit	2.5L DIESEL	RCM(Restraint Control Module)																											
Ford	Transit	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Transit	2.5L DIESEL	CSM(Central Security Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	RIM(Remote Immobilizer Module)																											
Ford	Transit	2.5L DIESEL	ACM(Audio Control Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Transit	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Transit	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Transit	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Transit	3.7L	TiVCT	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.7L	TiVCT	BCM(Body Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Ford	Transit	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Transit	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.7L	TiVCT	IPM-A(Image Processing Module A)																										
Ford	Transit	3.7L	TiVCT	IPM-B(Image Processing Module B)																										
Ford	Transit	3.7L	TiVCT	PAM(Park Aid Module)																										
Ford	Transit	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Transit	3.7L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.7L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.7L	TiVCT	TRM(Trailer Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Thunderbird	3.9L	4V	SYSTEM SEARCH																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ACM(Audio Control Module)																										
Ford	Thunderbird	3.9L	4V	DDM(Driver's Door Module)																										
Ford	Thunderbird	3.9L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Thunderbird	3.9L	4V	GEM(Generic Electronic Module)																										
Ford	Thunderbird	3.9L	4V	HEC(Hybrid Electrical Cluster)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	REM(Rear Electronic Module)																										
Lincoln	Aviator	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Aviator	4.6L	4V	PCM(Powertrain Control Module)																										
Lincoln	Aviator	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Aviator	4.6L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Aviator	4.6L	4V	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	Aviator	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Aviator	4.6L	4V	IC(Instrument Cluster)																										
Lincoln	Aviator	4.6L	4V	PAM(Parking Aid Module)																										
Lincoln	Aviator	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Aviator	4.6L	4V	TPM(Tire Pressure Monitor)																										
Lincoln	Aviator	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Lincoln	Aviator	4.6L	4V	VSM(Vehicle Security Module)																										
Lincoln	Continental	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Continental	4.6L	4V	PCM(PowerTrain Control Module)																										
Lincoln	Continental	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Continental	4.6L	4V	ACM(Audio Control Module)																										
Lincoln	Continental	4.6L	4V	CPM(Cellular Phone Module)																										
Lincoln	Continental	4.6L	4V	DDM(Driver's Door Module)																										
Lincoln	Continental	4.6L	4V	DSM(Driver's Seat Module)																										
Lincoln	Continental	4.6L	4V	LCM(Lighting Control Module)																										
Lincoln	Continental	4.6L	4V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Continental	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Continental	4.6L	4V	VDM(Vehicle Dynamic Module)																										
Lincoln	Continental	4.6L	4V	VIC(Virtual Image Cluster)																										
Lincoln	Continental	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Continental	4.6L	4V	PATS(Passive Anti Theft System)																										
Lincoln	LS	ALL	SYSTEM SEARCH																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	ABS(Anti-Lock Brake System)																											
Lincoln	LS	ALL	DCSM(Driver-Dual Climate Control Seat Module)																											
Lincoln	LS	ALL	DDM(Driver's Door Module)																											
Lincoln	LS	ALL	DSM(Driver's Seat Module)																											
Lincoln	LS	ALL	EPB(Electronic Parking Brake)																											
Lincoln	LS	ALL	PAM(Parking Aid Module)																											
Lincoln	LS	ALL	RCM(Restraint Control Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	SCLM(Steering Column Locking Module)																											
Lincoln	LS	ALL	EATC(Electronic Automatic Temperature Control)																											
Lincoln	LS	ALL	GEM(Generic Electronic Module)																											
Lincoln	LS	ALL	HEC(Hybrid Electrical Cluster)																											
Lincoln	LS	ALL	PCSM(Passenger Climate Control Seat Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	MKS	3.7L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKS	3.7L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.7L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2009	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2009	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2009	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2010 ~	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2010 ~	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Caliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	MKS	3.7L	4V	2010 ~	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2010 ~	HUD(Head Up Display)																									
Lincoln	MKS	3.7L	4V	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2010 ~	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKX	3.5L	4V	2007	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2007	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2007	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2007	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2007	EATC(Electronic Automatic Temperature Control)																									
Lincoln	MKX	3.5L	4V	2007	GEM(Generic Electronic Module)																									
Lincoln	MKX	3.5L	4V	2007	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2007	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2007	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2007	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2007	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2007	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2007	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2007	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2007	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2008	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2008	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2008	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2008	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2008	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2008	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	MKX	3.5L	4V	2008	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2008	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2008	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2008	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2008	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2008	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2008	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2008	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2008	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2009	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2009	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2009	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2009	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2009	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2010	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2010	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2010	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	MKX	3.5L	4V	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2010	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2010	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2010	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2010	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2010	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2010	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2010	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKZ	3.0L	2006	SYSTEM SEARCH																										
Lincoln	MKZ	3.0L	2006	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.0L	2006	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.0L	2006	ACM(Audio Control Module)																										
Lincoln	MKZ	3.0L	2006	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.0L	2006	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.0L	2006	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.0L	2006	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.0L	2006	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.0L	2006	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.0L	2006	IC(Instrument Cluster)																										
Lincoln	MKZ	3.0L	2006	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.0L	2006	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.0L	2006	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2007	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2007	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2007	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2007	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2007	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2007	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2007	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	MKZ	3.5L	2007	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2007	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.5L	2007	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.5L	2007	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2007	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2007	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2007	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2007	PATS(Passive Anti Theft System)																										
Lincoln	MKZ	3.5L	2008	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2008	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2008	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2008	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2008	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2008	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2008	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2008	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2008	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2008	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2008	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2008	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2008	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2008	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2008	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2008	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2009	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2009	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2009	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2009	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2009	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2009	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2009	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2009	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2009	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	MKZ	3.5L	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2009	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2009	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2009	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2009	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2009	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2009	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2009	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2010	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2010	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2010	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2010	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2010	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2010	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2010	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2010	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2010	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	3.5L	2010	FDIM(Front Display Interface Module)																										
Lincoln	MKZ	3.5L	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2010	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	3.5L	2010	HCM(Headlamp Control Module)																										
Lincoln	MKZ	3.5L	2010	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2010	ILCM(Interior Lighting Control Module)																										
Lincoln	MKZ	3.5L	2010	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	3.5L	2010	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2010	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2010	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2010	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	3.5L	2010	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	3.5L	2010	TCM(Transmission Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)											V															
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRCM(Transmission Range Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM(Body Control Module)											V															
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM(Transmission Range Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Lincoln	Navigator	2007 ~	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	APIM(Accessory Protocol Interface Module)																										
Lincoln	Navigator	2007 ~	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GPSM(Global Positioning System Module)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	2007 ~	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	2007 ~	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	2007 ~	5.4L	PRB(Power Running Board)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCU(Audio Rear Control Unit)																										
Lincoln	Navigator	2007 ~	5.4L	RETM(Rear Entertainment Module)																										
Lincoln	Navigator	2007 ~	5.4L	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	Navigator	2007 ~	5.4L	TCCM(Transfer Case Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	TCM(Transmission Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	2007 ~	5.4L	4X4(4x4 Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PATS(Passive Anti Theft System)																										
Lincoln	Navigator	~ 2007	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	GEM(Generic Electronic Module)																										
Lincoln	Navigator	~ 2007	5.4L	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Navigator	~ 2007	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	~ 2007	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	~ 2007	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	~ 2007	5.4L	RIM(Remote Immobilizer Module)																										
Lincoln	Navigator	~ 2007	5.4L	VSM(Vehicle Security Module)																										
Lincoln	Town Car	4.6L	2V	SYSTEM SEARCH																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	LCM(Lighting Control Module)																										
Lincoln	Town Car	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Lincoln	Town Car	4.6L	2V	DDM(Driver's Door Module)																										
Lincoln	Town Car	4.6L	2V	DSM(Driver's Seat Module)																										
Lincoln	Town Car	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Town Car	4.6L	2V	RATC(Rear Air Temperature Control)																										
Lincoln	Town Car	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Lincoln	Town Car	4.6L	2V	PAM(Parking Aid Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	HEC(Hybrid Electrical Cluster)																										
Lincoln	Town Car	4.6L	2V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Town Car	4.6L	2V	RASM(Rear Air Suspension Module)																										
Mercury	Grand Marquis	4.6L	2V	SYSTEM SEARCH																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	DDM(Driver's Door Module)																										
Mercury	Grand Marquis	4.6L	2V	IC(Instrument Cluster)																										
Mercury	Grand Marquis	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Grand Marquis	4.6L	2V	LCM(Lighting Control Module)																										
Mercury	Grand Marquis	4.6L	2V	MC(Message Center)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RIM(Remote Immobilizer Module)																										
Mercury	Grand Marquis	4.6L	2V	GEM(Generic Electronic Module)																										
Mercury	Grand Marquis	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Mercury	Marauder	4.6L	4V	SYSTEM SEARCH																										
Mercury	Marauder	4.6L	4V	PCM(Powertrain Control Module)																										
Mercury	Marauder	4.6L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Marauder	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Marauder	4.6L	4V	RASM(Rear Air Suspension Module)																										
Mercury	Marauder	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Mercury	Marauder	4.6L	4V	DDM(Driver's Door Module)																										
Mercury	Marauder	4.6L	4V	LCM(Lighting Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	Milan	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SYSTEM SEARCH																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Milan	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	Milan	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Milan	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	Milan	3.0L	4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Milan	3.0L	4V	PATS(Passive Anti Theft System)																										
Mercury	Montego	3.0L	4V	SYSTEM SEARCH																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Montego	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Montego	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Montego	3.0L	4V	DSM(Driver's Seat Module)																										
Mercury	Montego	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Montego	3.0L	4V	GEM(Generic Electronic Module)																										
Mercury	Montego	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Montego	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Montego	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Montego	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Mercury	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Mercury	Mountaineer	2010 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2010 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2010 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2010 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2010 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2010 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.6L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	Mountaineer	2009 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2009 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2009 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2009 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2009 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2008 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2008 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2008 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2008 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	Mountaineer	2007 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2007 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2007 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2007 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2007 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2006 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2006 MY	4.6L	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	Mountaineer	2006 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2006 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2006 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2006 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2006 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2003 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2003 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2003 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2003 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2003 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2003 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2003 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2002 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2002 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2002 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2002 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	Mountaineer	2002 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2002 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2001 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2001 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2001 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2001 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2001 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2001 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2000 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2000 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2000 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2000 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2000 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2000 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	1999 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1999 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1999 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1999 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1999 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1999 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	1998 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1998 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1998 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1998 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1998 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1997 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1997 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1997 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1997 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1997 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Reset/Clear Specified Function	Injector Quantity Adjustment	SCR System Emptying	SCR System Refill Activation	SCR Parameter Reset	SCR Visual Leak Check	SCR Dosing Measurement Test	DPF Parameter Reset	DPF Regeneration Suspension	LIN New Module Initialization	Key on engine run self test	Reset the Powertrain Control Module Learned Values	Reset transmission table	Reset learned values	Configure the lateral acceleration sensor	Configure the longitudinal acceleration sensor	Configure the pressure sensor	Configure the yaw rate sensor	Module initialization	Bleed-Brake Calliper	Bleed-Drum Brake-Wheel Cylinder	Bleed-Brake Hose	Bleed-Brake Tubes	Bleed-Brake Master Cylinder	Bleed-ABS module
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Vehicle Info.	Vehicle Info.	Vehicle Info.																												
Ford	Crown Victoria	4.6L	2V	SYSTEM SEARCH																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	DDM(Driver's Door Module)																										
Ford	Crown Victoria	4.6L	2V	IC(Instrument Cluster)																										
Ford	Crown Victoria	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Crown Victoria	4.6L	2V	LCM(Lighting Control Module)																										
Ford	Crown Victoria	4.6L	2V	MC(Message Center)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	Crown Victoria	4.6L	2V	GEM(Generic Electronic Module)																										
Ford	Crown Victoria	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.4L	DIESEL	SYSTEM SEARCH																										
Ford	Ecosport	1.4L	DIESEL	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.4L	DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.4L	DIESEL	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.4L	DIESEL	IC(Instrument Cluster)																										
Ford	Ecosport	1.4L	DIESEL	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	FFV	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Ecosport	1.6L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	FFV	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Escort	2.0L	SYSTEM SEARCH																											
Ford	Escort	2.0L	PCM(PowerTrain Control Module)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ECS(Electronic Crash Sensor)																											
Ford	Escort	2.0L	PATS(Passive Anti Theft System)																											
Ford	Escort	2.0L	RAP(Remote Anti-Theft/Personality Module)																											
Ford	Edge	3.5L	4V	SYSTEM SEARCH																										
Ford	Edge	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Edge	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Edge	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Edge	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	4V	IC(Instrument Cluster)																										
Ford	Edge	3.5L	4V	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Edge	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Edge	3.5L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Edge	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.5L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.5L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	TiVCT	RFA(Remote Function Actuator)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Edge	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.5L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.5L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Edge	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.7L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.7L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.7L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.7L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.7L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.7L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Edge	3.7L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.7L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.7L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.7L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.7L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.7L	TiVCT	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.7L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Escape	Up to 2004	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Escape	Up to 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	Up to 2004	Immobilizer																											
Ford	Escape	Up to 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	Up to 2004	RCM(Restraint Control Module)																											
Ford	Escape	Up to 2004	GEM(Generic Electronic Module)																											
Ford	Escape	From 2004	SYSTEM SEARCH																											
Ford	Escape	From 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	From 2004	PATS(Passive Anti Theft System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	RCM(Restraint Control Module)																											
Ford	Escape	From 2004	IC(Instrument cluster)																											
Ford	Escape	From 2004	GEM(Generic Electronic Module)																											
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Excursion	GASOLINE	SYSTEM SEARCH																											
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											
Ford	Excursion	GASOLINE	ABS(Anti-Lock Brake System)																											
Ford	Excursion	GASOLINE	CSM(Central Security Module)																											
Ford	Excursion	GASOLINE	DSM(Driver's Seat Module)																											
Ford	Excursion	GASOLINE	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	GASOLINE	ECS(Electronic Crash Sensor)																											
Ford	Excursion	GASOLINE	GEM(Generic Electronic Module)																											
Ford	Excursion	GASOLINE	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	GASOLINE	OTC(Overhead Trip Computer)																											
Ford	Excursion	GASOLINE	PAM(Parking Aid Module)																											
Ford	Excursion	GASOLINE	PATS(Passive Anti Theft System)																											
Ford	Excursion	GASOLINE	TCM(Transmission Control Module)																											
Ford	Excursion	GASOLINE	VSM(Vehicle Security Module)																											
Ford	Excursion	DIESEL	SYSTEM SEARCH																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Excursion	DIESEL	CSM(Central Security Module)																											
Ford	Excursion	DIESEL	DSM(Driver's Seat Module)																											
Ford	Excursion	DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	DIESEL	ECS(Electronic Crash Sensor)																											
Ford	Excursion	DIESEL	GEM(Generic Electronic Module)																											
Ford	Excursion	DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	DIESEL	OTC(Overhead Trip Computer)																											
Ford	Excursion	DIESEL	PAM(Parking Aid Module)																											
Ford	Excursion	DIESEL	PATS(Passive Anti Theft System)																											
Ford	Excursion	DIESEL	TCM(Transmission Control Module)																											
Ford	Excursion	DIESEL	VSM(Vehicle Security Module)																											
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	EATC(Electronic Automatic Temperature Control)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VSM(Vehicle Security Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TBC(Trailer Brake Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCCM(Transfer Case Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	GEM(Generic Electronic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	5.4L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VSM(Vehicle Security Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	APIM(Accessory Protocol Interface Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GPSM(Global Positioning System Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	4.6L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PRB(Power Running Board)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCU(Audio Rear Control Unit)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RETM(Rear Entertainment Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	TCM(Transmission Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	4X4(4x4 Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VSM(Vehicle Security Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2015 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2014 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PATS(Passive Anti Theft System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2012 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2010 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2009 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2005 MY	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2005 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2005 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2005 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2005 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2005 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2004 MY	SYSTEM SEARCH																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2004 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2004 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2004 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2004 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2004 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2003 MY	SYSTEM SEARCH																											
Ford	Explorer	2003 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2003 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2003 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2003 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2003 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2003 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2003 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2002 MY	SYSTEM SEARCH																											
Ford	Explorer	2002 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2002 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2002 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2002 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2002 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2002 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2002 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2001 MY	SYSTEM SEARCH																											
Ford	Explorer	2001 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2001 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2001 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2001 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer	2001 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2001 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	SYSTEM SEARCH																											
Ford	Explorer	2000 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2000 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2000 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	2000 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2000 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	1999 MY	SYSTEM SEARCH																											
Ford	Explorer	1999 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1999 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1999 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1999 MY	PAM(Parking Aid Module)																											
Ford	Explorer	1998 MY	SYSTEM SEARCH																											
Ford	Explorer	1998 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1998 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1998 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1998 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1997 MY	SYSTEM SEARCH																											
Ford	Explorer	1997 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1997 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1997 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1997 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer SportTrac	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer SportTrac	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer SportTrac	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2004 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	RAP(Remote Anti-Theft/Personality Module)																									
Ford	E-Series	5.4L	2V	2004 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2004 ~	VSM(Vehicle Security Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2009 ~	ACM(Audio Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	E-Series	5.4L	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	E-Series	5.4L	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	E-Series	5.4L	2V	2009 ~	IPC(Instrument Panel Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																										
Ford	F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																										
Ford	F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																									
Ford	F150	4.6L(BETA)	3V	SYSTEM SEARCH																										
Ford	F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																										
Ford	F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																										
Ford	F150	4.6L(BETA)	3V	ACM(Audio Control Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																										
Ford	F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																										
Ford	F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																										
Ford	F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	4.6L(BETA)	3V	IC(Instrument Cluster)																										
Ford	F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																										
Ford	F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																										
Ford	F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																										
Ford	F150	4.6L(BETA)	3V	PRB(Power Running Board)																										
Ford	F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																										
Ford	F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																										
Ford	F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																										
Ford	F150	5.0L	TiVCT	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	F150	5.0L	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	5.0L	TiVCT	ACM(Audio Control Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	5.0L	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	5.0L	TiVCT	IC(Instrument Cluster)																										
Ford	F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PRB(Power Running Board)																										
Ford	F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	5.0L	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	5.0L	TiVCT	TCM(Transmission Control Module)																										
Ford	F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	F150	5.4L	3V	2009 ~	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2009 ~	PRB(Power Running Board)																									
Ford	F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	6.2L(BETA)	2V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																										
Ford	F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																										
Ford	F150	6.2L(BETA)	2V	ACM(Audio Control Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																										
Ford	F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																										
Ford	F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																										
Ford	F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																										
Ford	F150	6.2L(BETA)	2V	IC(Instrument Cluster)																										
Ford	F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																										
Ford	F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																										
Ford	F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																										
Ford	F150	6.2L(BETA)	2V	PRB(Power Running Board)																										
Ford	F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																										
Ford	F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																										
Ford	F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																										
Ford	F150	Other	2004 ~ 2008	SYSTEM SEARCH																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																										
Ford	F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																										
Ford	F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																										
Ford	F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	Other	2004 ~ 2008	IC(Instrument Cluster)																										
Ford	F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										
Ford	F250	7.3L	SYSTEM SEARCH																											
Ford	F250	7.3L	PCM(PowerTrain Control Module)																											
Ford	F250	7.3L	ABS(Anti-Lock Brake System)																											
Ford	F250	7.3L	ECS(Electronic Crash Sensor)																											
Ford	F250	7.3L	GEM(Generic Electronic Module)																											
Ford	F250	6.2L	SYSTEM SEARCH																											
Ford	F250	6.2L	PCM(Powertrain Control Module)																											
Ford	F250	6.2L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.2L	ACM(Audio Control Module)																											
Ford	F250	6.2L	APIM(Accessory Protocol Control Module)																											
Ford	F250	6.2L	BCMii(Body Control Module)																											
Ford	F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																											
Ford	F250	6.2L	DSM(Driver Seat Module)																											
Ford	F250	6.2L	GPSM(Global Positioning System Module)																											
Ford	F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F250	6.2L	IPC(Instrument Panel Control Module)																											
Ford	F250	6.2L	PAM(Parking Aid Module)																											
Ford	F250	6.2L	RCM(Restraint Control Module)																											
Ford	F250	6.2L	SCCM(Streering Colume Control Module)																											
Ford	F250	6.2L	TBC(Trailer Brake Control Module)																											
Ford	F250	6.2L	TCCM(Transfer Case Control Module)																											
Ford	F250	6.2L	TPM(Tire Pressure Monitor)																											
Ford	F250	6.0L	SYSTEM SEARCH																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.0L	GEM(Generic Electronic Module)																											
Ford	F250	6.0L	HEC(Hybrid Electrical Cluster)																											
Ford	F250	6.0L	OTC(Overhead Trip Computer)																											
Ford	F250	6.0L	PAM(Parking Aid Module)																											
Ford	F250	6.0L	PATS(Passive Anti Theft System)																											
Ford	F250	6.0L	RCM(Restraint Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	VSM(Vehicle Security Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SYSTEM SEARCH																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM(PowerTrain Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4(4x4 Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS(Anti-Lock Brake System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM(Audio Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM(Auxiliary Heater Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM(Accessory Protocol Interface Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM(Circuit Deactivation Ignition Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM(Driver's Seat Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GPSM(Global Positioning System Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC(Instrument Cluster)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM(Parking Aid Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM(Restraint Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM(Rear Entertainment Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS(Satellite Digital Audio Receiver System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC(Trailer Brake Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM(Transmission Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																									
Ford	Fiesta	1.4L	DURATEC 16V	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)		V	V																							
Ford	Fiesta	1.4L	DURATEC 16V	PSCM(Power Steering Control Module)				V	V	V	V																			
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)								V																		
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)									V																	
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)										V	V	V	V													
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)														V												
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)								V																		
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)					V									V												
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)								V																		
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)															V	V										
Ford	Fiesta	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)		V	V																							
Ford	Fiesta	1.6L	DURATEC	PSCM(Power Steering Control Module)				V	V	V	V																			
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)								V																		
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)									V																	
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)								V																		
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	BCMii(Body Control Module)																										
Ford	Fiesta	1.6L	DURATEC	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																	V									
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																		V	V							
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	BCM(Body Control Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Fiesta	1.6L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	PSCM(Power Steering Control Module)																				V	V					
Ford	Fiesta	1.6L	TiVCT	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.6L	TiVCT	VSM(Vehicle Security Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	Zetec Rocam	IC(Instrument Cluster)																										
Ford	Fiesta	1.6L	Zetec Rocam	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	RKE(Remote Keyless Entry)																										
Ford	Fiesta	1.6L	Zetec Rocam	TCM(Transmission Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	SYSTEM SEARCH																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																										
Ford	Fiesta	2.0L	SYSTEM SEARCH																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)			V	V																							
Ford	Fiesta	2.0L	ACM(Audio Control Module)									V																		
Ford	Fiesta	2.0L	EATC(Electronic Automatic Temperature Control)																											
Ford	Fiesta	2.0L	GEM(Generic Electronic Module)									V																		
Ford	Fiesta	2.0L	IC(Instrument Cluster)									V																		
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	RCM(Restraint Control Module)																											
Ford	Fiesta	2.0L	PATS(Passive Anti Theft System)-BETA																V	V										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																						V				
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																							V	V		
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Focus	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	ZETEC ROCAM	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Focus	1.6L	ZETEC ROCAM	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																								V	V
Ford	Focus	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EPS(Electronic power steering)								V																		
Ford	Focus	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)								V																		
Ford	Focus	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)								V																		
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)		V	V																							
Ford	Focus	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Focus	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)							V																			
Ford	Focus	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)										V																
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									V	
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic power steering)								V																		
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)								V																		
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)								V																		
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ACM(Audio control module)																										
Ford	Focus	1.8L	DURATEC HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.8L	DURATEC HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.8L	DURATEC HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.8L	DURATEC HE/I4	EPS(Electronic power steering)								V																		
Ford	Focus	1.8L	DURATEC HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)								V																		
Ford	Focus	1.8L	DURATEC HE/I4	IC(Instrument cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	NAV(Navigation System)																										
Ford	Focus	1.8L	DURATEC HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PDM(Passenger's Door Module)								V																		
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)								V																		
Ford	Focus	1.8L	DURATEC HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	MC(Message Center)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FDIM(Front Display Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TCM(Transmission control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)								V																		
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CSM(Central Security Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	D_DCU(Driver Door Control Unit)								V																		
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EPS(Electronic power steering)								V																		
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GDM(Generic Display Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)								V																		
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)								V																		
Ford	Focus	2.0L DURATEC	2003 ~ 2007	NAV(Navigation System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PDM(Passenger's Door Module)								V																		
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RKE(Remote Keyless Entry)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TBM(Tracking And Blocking Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SRM(Speech recognition module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)								V																		
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SYSTEM SEARCH																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ACM(Audio Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	BCM(Body Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DDM(Driver's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	IPC(Instrument Panel Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PAM(Parking Aid Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PSCM(Power Steering Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SASM(Steering Angle Sensor Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Focus	2.0L DIESEL	2003 ~ 2008	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EPS(Electronic power steering)								V																		
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FACM(Fuel Additive Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	GEM(Generic Electronic Module)								V																		
Ford	Focus	2.0L DIESEL	2003 ~ 2008	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PAM(Parking Aid Module)								V																		
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RETM(Rear Entertainment Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RKE(Remote Keyless Entry)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	TCM(Transmission control module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ABS(Anti-Lock Brake System)								V																		
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	EPS(Electronic power steering)								V																		
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	RCM(Restraint Control Module)								V																		
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	GEM(Generic Electronic Module)								V																		
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	DDM(Driver's Door Module)								V																		
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PDM(Passenger's Door Module)								V																		
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	MC(Message Center)								V																		
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ACM(Audio control module)								V																		
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)										V																
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)										V	V						V									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									V	
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)								V																		
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)								V																		
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)								V																		
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA															V	V										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EPS(Electronic Power Steering)								V																		
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)								V																		
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)								V																		
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)		V	V																							
Ford	Focus C-MAX	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Focus C-MAX	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)							V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)								V																	V	V
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)								V																		
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPS(Electronic Power Steering)								V																		
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GEM(Generic Electronic Module)								V																		
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PDM(Passenger's Door Module)								V																		
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)								V																	V	V
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)								V																		
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPS(Electronic Power Steering)								V																		
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)								V																		
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PDM(Passenger's Door Module)								V																		
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Flex	3.5L	4V	SYSTEM SEARCH																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	4V	ACM(Audio control module)																										
Ford	Flex	3.5L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	4V	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	4V	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	4V	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	4V	IC(Instrument cluster)																										
Ford	Flex	3.5L	4V	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	4V	LTM(Liftgate/Trunk Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Flex	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	4V	Factory Keyless Entry Code																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio control module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC(Instrument cluster)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Flex	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	TiVCT	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Flex	3.5L	TiVCT	ACM(Audio control module)																										
Ford	Flex	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	TiVCT	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	TiVCT	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	TiVCT	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	TiVCT	IC(Instrument cluster)																										
Ford	Flex	3.5L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	TiVCT	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Ford	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Ford	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Ford	Freestyle	3.0L	4V	SYSTEM SEARCH																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Freestyle	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Freestyle	3.0L	4V	ACM(Audio Control Module)																										
Ford	Freestyle	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Freestyle	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Freestyle	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Freestyle	3.0L	4V	IC(Instrument Cluster)																										
Ford	Freestyle	3.0L	4V	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Freestyle	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Freestyle	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Five Hundred	3.0L	4V	SYSTEM SEARCH																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Five Hundred	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Five Hundred	3.0L	4V	ACM(Audio Control Module)																										
Ford	Five Hundred	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Five Hundred	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Five Hundred	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Five Hundred	3.0L	4V	IC(Instrument Cluster)																										
Ford	Five Hundred	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Five Hundred	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Five Hundred	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Ford GT	5.4L	4V	SYSTEM SEARCH																										
Ford	Ford GT	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	IC(Instrument Cluster)																										
Ford	Ford GT	5.4L	4V	PATS(Passive Anti Theft System)																										
Ford	Ford GT	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)							V																			
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	TCM(Transmission control module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Fusion	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	DURATEC	IC(Instrument cluster)								V																		
Ford	Fusion	1.6L	DURATEC	ACM(Audio control module)																										
Ford	Fusion	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fusion	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																		V	V							
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																		V	V							
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SYSTEM SEARCH																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																		V	V							
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BCM(Body Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HUD(Head Up Display)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM(Secondary OBD Control Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	TCU(Telematic Control Unit Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Fusion	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.5L	IVCT	SYSTEM SEARCH																										
Ford	Fusion	2.5L	IVCT	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	IVCT	ABS(Anti-Lock Brake System)																		V	V							
Ford	Fusion	2.5L	IVCT	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	IVCT	BCM(Body Control Module)																										
Ford	Fusion	2.5L	IVCT	C-CM(Cruise Control Module)																										
Ford	Fusion	2.5L	IVCT	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.5L	IVCT	DDM(Driver's Door Module)																										
Ford	Fusion	2.5L	IVCT	DSM(Driver's Seat Module)																										
Ford	Fusion	2.5L	IVCT	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	IVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.5L	IVCT	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	IVCT	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	IVCT	GWM(Gateway Module A)																										
Ford	Fusion	2.5L	IVCT	HUD(Head Up Display)																										
Ford	Fusion	2.5L	IVCT	IPC(Instrument Panel Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Fusion	2.5L	IVCT	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.5L	IVCT	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	IVCT	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	IVCT	PDM(Passenger's Door Module)																										
Ford	Fusion	2.5L	IVCT	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	IVCT	RACM(Rear Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	IVCT	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.5L	IVCT	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.5L	IVCT	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.5L	IVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	IVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.0L	4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Fusion	3.5L	4V	SYSTEM SEARCH																										
Ford	Fusion	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.5L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.5L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.5L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.5L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.5L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	KA	2000 MY	SYSTEM SEARCH																											
Ford	KA	2000 MY	PCM(PowerTrain Control Module)																											
Ford	KA	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	KA	2000 MY	RCM(Restraint Control Module)																											
Ford	KA	1999 MY	PCM(PowerTrain Control Module)																											
Ford	KA	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Kuga	2.0L DIESEL	SYSTEM SEARCH																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)														V													
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)											V	V															
Ford	Kuga	2.0L DIESEL	TCM(Transmission Control Module)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																									V	V
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																											
Ford	Kuga	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																											
Ford	Kuga	2.0L DIESEL	AWD(All Wheel Drive Module)																											
Ford	Kuga	2.0L DIESEL	BCMii(Body Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Kuga	2.0L DIESEL	CCMii(Cruise Control Module)																											
Ford	Kuga	2.0L DIESEL	CMR(Camera Module Rear)																											
Ford	Kuga	2.0L DIESEL	D_DCU(Driver Door Control Unit)																											
Ford	Kuga	2.0L DIESEL	DDM(Driver's Door Module)																											
Ford	Kuga	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Kuga	2.0L DIESEL	EPS(Electronic Power Steering)									V																		
Ford	Kuga	2.0L DIESEL	FDSM(Front Distance Sensing Module)																											
Ford	Kuga	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																											
Ford	Kuga	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Kuga	2.0L DIESEL	GEM(Generic Electronic Module)									V																		
Ford	Kuga	2.0L DIESEL	GPSM(Global Positioning System Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Kuga	2.0L DIESEL	IPM-A(Image Processing Module A)																											
Ford	Kuga	2.0L DIESEL	IPM-B(Image Processing Module B)																											
Ford	Kuga	2.0L DIESEL	IPC(Instrument Panel Control Module)																											
Ford	Kuga	2.0L DIESEL	IC(Instrument Cluster)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PSCM(Power Steering Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RFA(Remote Function Actuator)																											
Ford	Kuga	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																											
Ford	Kuga	2.0L DIESEL	RETM(Rear Entertainment Module)																											
Ford	Kuga	2.0L DIESEL	SASM(Steering Angle Sensor Module)																											
Ford	Kuga	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Kuga	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Kuga	2.0L DIESEL	SRM(Speech Recognition Module)																											
Ford	Kuga	2.0L DIESEL	TRM(Trailer Module)																											
Ford	Kuga	2.5L	I5	SYSTEM SEARCH																										
Ford	Kuga	2.5L	I5	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.5L	I5	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.5L	I5	ACM(Audio Control Module)																										
Ford	Kuga	2.5L	I5	AWD(All Wheel Drive Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Kuga	2.5L	I5	CMR(Camera Module Rear)																										
Ford	Kuga	2.5L	I5	D_DCU(Driver Door Control Unit)																										
Ford	Kuga	2.5L	I5	EATC(Electronic Automatic Temperature Control)																										
Ford	Kuga	2.5L	I5	EPS(Electronic Power Steering)								V																		
Ford	Kuga	2.5L	I5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Kuga	2.5L	I5	GEM(Generic Electronic Module)								V																		
Ford	Kuga	2.5L	I5	HCM(Headlamp Control Module)																										
Ford	Kuga	2.5L	I5	IC(Instrument Cluster)																										
Ford	Kuga	2.5L	I5	PAM(Parking Aid Module)																										
Ford	Kuga	2.5L	I5	PDM(Passenger's Door Module)																										
Ford	Kuga	2.5L	I5	RCM(Restraint Control Module)																										
Ford	Kuga	2.5L	I5	RETM(Rear Entertainment Module)																										
Ford	Kuga	2.5L	I5	RKE(Remote Keyless Entry)																										
Ford	Kuga	2.5L	I5	SRM(Speech Recognition Module)																										
Ford	Kuga	2.5L	I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)										V	V	V	V													
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)		V																							V	
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Mondeo	2010 MY	2.5L I5	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.5L I5	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.5L I5	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.5L I5	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.5L I5	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.5L I5	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.5L I5	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.5L I5	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SYSTEM SEARCH																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	AHCM(Auxiliary Heater Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	BCMii(Body Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CCMii(Cruise Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DDM(Driver's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DSM(Driver's Seat Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HCM(HeadLamp Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RFA(Remote Function Actuator)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TRM(Trailer Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ACM(Audio Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	CDP(Compact Disc Player)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GDM(Generic Display Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	NAV(Navigation System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SRM(Speech Recognition Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	SYSTEM SEARCH																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	GEM(Generic Electronic Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	HCM(Headlamp Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2000 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	2000 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	2000 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1999 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1999 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Mondeo	1998 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1998 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1998 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1997 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1997 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1997 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1997 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	BCM-B(Body Control Module B)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Mustang	3.7L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Mustang	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Mustang	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Mustang	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Mustang	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Mustang	3.7L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.8L	SYSTEM SEARCH																											
Ford	Mustang	3.8L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.8L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.8L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.8L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.8L	RCM(Restraint Control Module)																											
Ford	Mustang	3.9L	SYSTEM SEARCH																											
Ford	Mustang	3.9L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.9L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.9L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.9L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.9L	RCM(Restraint Control Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	BCM-B(Body Control Module B)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.0L	V6 (SOHC)	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.0L	V6 (SOHC)	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Mustang	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Mustang	4.0L	V6 (SOHC)	PAM(Parking Aid Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PSCM(Power Steering Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Mustang	4.0L	V6 (SOHC)	PATS(Passive Anti Theft System)-BETA																V										
Ford	Mustang	4.6L	3V	SYSTEM SEARCH																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	BCM-B(Body Control Module B)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	PATS(Passive Anti Theft System)-BETA																V										
Ford	Mustang	5.0L	~ 2014	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FDIM(Front Display Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ABS(Anti-Lock Brake System)																V	V								
Ford	Mustang	5.0L	2015 ~	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM(Body Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	C-CM(Cruise Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DACM-C(Digital Audio Control Module C)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DDM(Driver's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSM(Driver's Seat Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GWM(Gateway Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	HUD(Head Up Display)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ICM(Information Center Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-A(Movable Roof Control Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-B(Movable Roof Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PAM(Parking Aid Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PDM(Passenger's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Mustang	5.0L	2015 ~	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	RTM(Radio Transceiver Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCM-E(Seat Control Module E)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Mustang	5.4L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	BCM-B(Body Control Module B)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.4L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.4L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.4L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.4L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.4L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.4L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	BCM-B(Body Control Module B)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.8L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.8L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.8L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.8L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.8L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.8L	4V	PAM(Parking Aid Module)																										
Ford	Mustang	5.8L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																	V	V								
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM-B(Body Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ICM(Information Center Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-A(Movable Roof Control Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-B(Movable Roof Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)										V	V	V					V									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Diesel(WL-CD)	SYSTEM SEARCH																											
Ford	Ranger	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.0 Diesel(WE-CD)	SYSTEM SEARCH																											
Ford	Ranger	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Ranger	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)										V	V	V					V									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Gasoline	SYSTEM SEARCH																											
Ford	Ranger	2.5 Gasoline	PCM(PowerTrain Control Module)																		V									
Ford	Ranger	2.5 Gasoline	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Gasoline	ACM(Audio Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Ranger	2.5 Gasoline	BCMii(Body Control Module)																											
Ford	Ranger	2.5 Gasoline	DDM(Driver's Door Module)																											
Ford	Ranger	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																											
Ford	Ranger	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Ranger	2.5 Gasoline	IPC(Instrument Panel Control Module)																											
Ford	Ranger	2.5 Gasoline	PAM(Parking Aid Module)																											
Ford	Ranger	2.5 Gasoline	PDM(Passenger's Door Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	SRM(Speech Recognition Module)																											
Ford	Ranger	2.5 Gasoline	TBM(Tracking And Blocking Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TRM(Trailer Module)																											
Ford	Ranger	2.5 Gasoline	PATS(Passive Anti Theft System)-BETA																											
Ford	Ranger	3.0L	Other	SYSTEM SEARCH																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	Other	IC(Instrument Cluster)																										
Ford	Ranger	3.0L	Other	OCSM(Occupant Classification System Module)																										
Ford	Ranger	3.0L	Other	4X4(4x4 Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	3.0L	FFV	SYSTEM SEARCH																										
Ford	Ranger	3.0L	FFV	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	FFV	PATS(Passive Anti Theft System)																										
Ford	Ranger	3.0L	FFV	RAP(Remote Anti-Theft/Personality Module)																										
Ford	Ranger	3.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Ranger	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Ranger	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Ranger	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Ranger	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	4X4(4x4 Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	IC(Instrument Cluster)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	LTM(Liftgate/Trunk Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SECM(Steering Effort Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HUD(Head Up Display)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	BCM(Body Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Taurus	3.5L	TiVCT	2013 ~	GFM(Generic Function Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RACM(Rear Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SCCM(Steering Column Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.0L	2000 ~	SYSTEM SEARCH																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	2000 ~	EATC(Electronic Automatic Temperature Control)																										
Ford	Taurus	3.0L	2000 ~	GEM(Generic Electronic Module)																										
Ford	Taurus	3.0L	2000 ~	IC(Instrument Cluster)																										
Ford	Taurus	3.0L	2000 ~	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	SYSTEM SEARCH																										
Ford	Taurus	3.0L	~ 1999	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	~ 1999	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	~ 1999	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	RIM(Remote Immobilizer Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SYSTEM SEARCH																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PCM(PowerTrain Control Module)													V													
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ABS(Anti-Lock Brake System)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ACM(Audio Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	GEM(Generic Electronic Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	IC(Instrument Cluster)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PAM(Parking Aid Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	RCM(Restraint Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SRM(Speech Recognition Module)																										
Ford	Transit	2.0L	2001 ~ 2004	SYSTEM SEARCH																										
Ford	Transit	2.0L	2001 ~ 2004	PCM(PowerTrain Control Module)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.0L	2001 ~ 2004	ASM(Auto Shift Manual)																										
Ford	Transit	2.0L	2001 ~ 2004	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.0L	2001 ~ 2004	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	CSM(Central Security Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2006.5	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2006.5	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	2.4L DIESEL	2006.5	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	PAM(Parking Aid Module)																										
Ford	Transit	2.4L DIESEL	2006.5	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	TBM(Tracking And Blocking Module)																										
Ford	Transit	2.5L DIESEL	SYSTEM SEARCH																											
Ford	Transit	2.5L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	ASM(Auto Shift Manual)																											
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																										
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Transit	2.5L DIESEL	RCM(Restraint Control Module)																											
Ford	Transit	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Transit	2.5L DIESEL	CSM(Central Security Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	RIM(Remote Immobilizer Module)																											
Ford	Transit	2.5L DIESEL	ACM(Audio Control Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Transit	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Transit	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Transit	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Transit	3.7L	TiVCT	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.7L	TiVCT	BCM(Body Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Ford	Transit	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Transit	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.7L	TiVCT	IPM-A(Image Processing Module A)																										
Ford	Transit	3.7L	TiVCT	IPM-B(Image Processing Module B)																										
Ford	Transit	3.7L	TiVCT	PAM(Park Aid Module)																										
Ford	Transit	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Transit	3.7L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.7L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.7L	TiVCT	TRM(Trailer Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)													V													
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Thunderbird	3.9L	4V	SYSTEM SEARCH																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ACM(Audio Control Module)																										
Ford	Thunderbird	3.9L	4V	DDM(Driver's Door Module)																										
Ford	Thunderbird	3.9L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Thunderbird	3.9L	4V	GEM(Generic Electronic Module)																										
Ford	Thunderbird	3.9L	4V	HEC(Hybrid Electrical Cluster)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	REM(Rear Electronic Module)																										
Lincoln	Aviator	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Aviator	4.6L	4V	PCM(Powertrain Control Module)																										
Lincoln	Aviator	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Aviator	4.6L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Aviator	4.6L	4V	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	Aviator	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Aviator	4.6L	4V	IC(Instrument Cluster)																										
Lincoln	Aviator	4.6L	4V	PAM(Parking Aid Module)																										
Lincoln	Aviator	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Aviator	4.6L	4V	TPM(Tire Pressure Monitor)																										
Lincoln	Aviator	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Lincoln	Aviator	4.6L	4V	VSM(Vehicle Security Module)																										
Lincoln	Continental	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Continental	4.6L	4V	PCM(PowerTrain Control Module)																										
Lincoln	Continental	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Continental	4.6L	4V	ACM(Audio Control Module)																										
Lincoln	Continental	4.6L	4V	CPM(Cellular Phone Module)																										
Lincoln	Continental	4.6L	4V	DDM(Driver's Door Module)																										
Lincoln	Continental	4.6L	4V	DSM(Driver's Seat Module)																										
Lincoln	Continental	4.6L	4V	LCM(Lighting Control Module)																										
Lincoln	Continental	4.6L	4V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Continental	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Continental	4.6L	4V	VDM(Vehicle Dynamic Module)																										
Lincoln	Continental	4.6L	4V	VIC(Virtual Image Cluster)																										
Lincoln	Continental	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Continental	4.6L	4V	PATS(Passive Anti Theft System)																										
Lincoln	LS	ALL	SYSTEM SEARCH																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	ABS(Anti-Lock Brake System)																											
Lincoln	LS	ALL	DCSM(Driver-Dual Climate Control Seat Module)																											
Lincoln	LS	ALL	DDM(Driver's Door Module)																											
Lincoln	LS	ALL	DSM(Driver's Seat Module)																											
Lincoln	LS	ALL	EPB(Electronic Parking Brake)																											
Lincoln	LS	ALL	PAM(Parking Aid Module)																											
Lincoln	LS	ALL	RCM(Restraint Control Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	SCLM(Steering Column Locking Module)																											
Lincoln	LS	ALL	EATC(Electronic Automatic Temperature Control)																											
Lincoln	LS	ALL	GEM(Generic Electronic Module)																											
Lincoln	LS	ALL	HEC(Hybrid Electrical Cluster)																											
Lincoln	LS	ALL	PCSM(Passenger Climate Control Seat Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	MKS	3.7L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKS	3.7L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.7L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2009	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2009	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2009	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2010 ~	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2010 ~	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	MKS	3.7L	4V	2010 ~	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2010 ~	HUD(Head Up Display)																									
Lincoln	MKS	3.7L	4V	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2010 ~	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKX	3.5L	4V	2007	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2007	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2007	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2007	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2007	EATC(Electronic Automatic Temperature Control)																									
Lincoln	MKX	3.5L	4V	2007	GEM(Generic Electronic Module)																									
Lincoln	MKX	3.5L	4V	2007	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2007	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2007	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2007	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2007	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2007	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2007	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2007	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2007	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2008	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2008	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2008	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2008	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2008	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2008	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	MKX	3.5L	4V	2008	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2008	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2008	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2008	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2008	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2008	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2008	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2008	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2008	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2009	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2009	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2009	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2009	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2009	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2010	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2010	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2010	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	MKX	3.5L	4V	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2010	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2010	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2010	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2010	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2010	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2010	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2010	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKZ	3.0L	2006	SYSTEM SEARCH																										
Lincoln	MKZ	3.0L	2006	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.0L	2006	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.0L	2006	ACM(Audio Control Module)																										
Lincoln	MKZ	3.0L	2006	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.0L	2006	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.0L	2006	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.0L	2006	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.0L	2006	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.0L	2006	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.0L	2006	IC(Instrument Cluster)																										
Lincoln	MKZ	3.0L	2006	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.0L	2006	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.0L	2006	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2007	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2007	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2007	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2007	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2007	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2007	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2007	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	MKZ	3.5L	2007	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2007	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.5L	2007	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.5L	2007	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2007	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2007	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2007	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2007	PATS(Passive Anti Theft System)																										
Lincoln	MKZ	3.5L	2008	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2008	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2008	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2008	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2008	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2008	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2008	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2008	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2008	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2008	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2008	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2008	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2008	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2008	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2008	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2008	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2009	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2009	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2009	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2009	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2009	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2009	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2009	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2009	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2009	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	MKZ	3.5L	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2009	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2009	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2009	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2009	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2009	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2009	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2009	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2010	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2010	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2010	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2010	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2010	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2010	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2010	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2010	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2010	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	3.5L	2010	FDIM(Front Display Interface Module)																										
Lincoln	MKZ	3.5L	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2010	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	3.5L	2010	HCM(Headlamp Control Module)																										
Lincoln	MKZ	3.5L	2010	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2010	ILCM(Interior Lighting Control Module)																										
Lincoln	MKZ	3.5L	2010	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	3.5L	2010	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2010	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2010	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2010	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	3.5L	2010	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	3.5L	2010	TCM(Transmission Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																		V	V							
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRCM(Transmission Range Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																		V	V							
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM(Body Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM(Transmission Range Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Lincoln	Navigator	2007 ~	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	APIM(Accessory Protocol Interface Module)																										
Lincoln	Navigator	2007 ~	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GPSM(Global Positioning System Module)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	2007 ~	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	2007 ~	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	2007 ~	5.4L	PRB(Power Running Board)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCU(Audio Rear Control Unit)																										
Lincoln	Navigator	2007 ~	5.4L	RETM(Rear Entertainment Module)																										
Lincoln	Navigator	2007 ~	5.4L	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	Navigator	2007 ~	5.4L	TCCM(Transfer Case Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	TCM(Transmission Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	2007 ~	5.4L	4X4(4x4 Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PATS(Passive Anti Theft System)																										
Lincoln	Navigator	~ 2007	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	GEM(Generic Electronic Module)																										
Lincoln	Navigator	~ 2007	5.4L	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Navigator	~ 2007	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	~ 2007	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	~ 2007	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	~ 2007	5.4L	RIM(Remote Immobilizer Module)																										
Lincoln	Navigator	~ 2007	5.4L	VSM(Vehicle Security Module)																										
Lincoln	Town Car	4.6L	2V	SYSTEM SEARCH																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	LCM(Lighting Control Module)																										
Lincoln	Town Car	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Lincoln	Town Car	4.6L	2V	DDM(Driver's Door Module)																										
Lincoln	Town Car	4.6L	2V	DSM(Driver's Seat Module)																										
Lincoln	Town Car	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Town Car	4.6L	2V	RATC(Rear Air Temperature Control)																										
Lincoln	Town Car	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Lincoln	Town Car	4.6L	2V	PAM(Parking Aid Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	HEC(Hybrid Electrical Cluster)																										
Lincoln	Town Car	4.6L	2V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Town Car	4.6L	2V	RASM(Rear Air Suspension Module)																										
Mercury	Grand Marquis	4.6L	2V	SYSTEM SEARCH																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	DDM(Driver's Door Module)																										
Mercury	Grand Marquis	4.6L	2V	IC(Instrument Cluster)																										
Mercury	Grand Marquis	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Grand Marquis	4.6L	2V	LCM(Lighting Control Module)																										
Mercury	Grand Marquis	4.6L	2V	MC(Message Center)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RIM(Remote Immobilizer Module)																										
Mercury	Grand Marquis	4.6L	2V	GEM(Generic Electronic Module)																										
Mercury	Grand Marquis	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Mercury	Marauder	4.6L	4V	SYSTEM SEARCH																										
Mercury	Marauder	4.6L	4V	PCM(Powertrain Control Module)																										
Mercury	Marauder	4.6L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Marauder	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Marauder	4.6L	4V	RASM(Rear Air Suspension Module)																										
Mercury	Marauder	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Mercury	Marauder	4.6L	4V	DDM(Driver's Door Module)																										
Mercury	Marauder	4.6L	4V	LCM(Lighting Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	Milan	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SYSTEM SEARCH																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Milan	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	Milan	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Milan	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	Milan	3.0L	4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Milan	3.0L	4V	PATS(Passive Anti Theft System)																										
Mercury	Montego	3.0L	4V	SYSTEM SEARCH																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Montego	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Montego	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Montego	3.0L	4V	DSM(Driver's Seat Module)																										
Mercury	Montego	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Montego	3.0L	4V	GEM(Generic Electronic Module)																										
Mercury	Montego	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Montego	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Montego	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Montego	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Mercury	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Mercury	Mountaineer	2010 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2010 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2010 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2010 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2010 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2010 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.6L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	Mountaineer	2009 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2009 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2009 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2009 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2009 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2008 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2008 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2008 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2008 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	Mountaineer	2007 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2007 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2007 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2007 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2007 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2006 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2006 MY	4.6L	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	Mountaineer	2006 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2006 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2006 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2006 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2006 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2003 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2003 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2003 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2003 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2003 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2003 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2003 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2002 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2002 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2002 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2002 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	Mountaineer	2002 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2002 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2001 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2001 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2001 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2001 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2001 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2001 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2000 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2000 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2000 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2000 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2000 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2000 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	1999 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1999 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1999 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1999 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1999 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1999 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	1998 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1998 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1998 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1998 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1998 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1997 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1997 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1997 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1997 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1997 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powertrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Bleed-Brake Fluid Change	Rear Brake Adjustment	Calibration steering angle sensor	Configure the steering comlumn assembly	Configure the Intermediate Shaft	Pull Drift Compensation	Module installation	Parameter Reset Clear Crash Data Memory	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the water in fuel Warning Indicator	Reset the Fuel Metering Valve Learned Values	Calibrate Steering Angle Sensor(EPS)	Ignition key erase	Ignition key programming	Reset the Powerrain Control Module Learned Valus	Inlet Valve Calibration	Isolation Valve Calibration	Steering Wheel Position Calibration	Electronic Power Assist Steering Configuration-Beta	Ignition Key Erase	PCM/IC Paramenter Reset	Odometer Write	ABS/ESP Service Bleed	ESP Configure All Three sensros Togethers.
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Vehicle Info.	Vehicle Info.	Vehicle Info.																												
Ford	Crown Victoria	4.6L	2V	SYSTEM SEARCH																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	DDM(Driver's Door Module)																										
Ford	Crown Victoria	4.6L	2V	IC(Instrument Cluster)																										
Ford	Crown Victoria	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Crown Victoria	4.6L	2V	LCM(Lighting Control Module)																										
Ford	Crown Victoria	4.6L	2V	MC(Message Center)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	Crown Victoria	4.6L	2V	GEM(Generic Electronic Module)																										
Ford	Crown Victoria	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.4L	DIESEL	SYSTEM SEARCH																										
Ford	Ecosport	1.4L	DIESEL	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.4L	DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.4L	DIESEL	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.4L	DIESEL	IC(Instrument Cluster)																										
Ford	Ecosport	1.4L	DIESEL	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	FFV	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Ecosport	1.6L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	FFV	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Escort	2.0L	SYSTEM SEARCH																											
Ford	Escort	2.0L	PCM(PowerTrain Control Module)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ECS(Electronic Crash Sensor)																											
Ford	Escort	2.0L	PATS(Passive Anti Theft System)																											
Ford	Escort	2.0L	RAP(Remote Anti-Theft/Personality Module)																											
Ford	Edge	3.5L	4V	SYSTEM SEARCH																										
Ford	Edge	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Edge	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Edge	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Edge	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	4V	IC(Instrument Cluster)																										
Ford	Edge	3.5L	4V	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Edge	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Edge	3.5L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Edge	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.5L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.5L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	TiVCT	RFA(Remote Function Actuator)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Edge	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.5L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.5L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Edge	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.7L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.7L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.7L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.7L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.7L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.7L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Edge	3.7L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.7L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.7L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.7L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.7L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.7L	TiVCT	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.7L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Escape	Up to 2004	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Escape	Up to 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	Up to 2004	Immobilizer																											
Ford	Escape	Up to 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	Up to 2004	RCM(Restraint Control Module)																											
Ford	Escape	Up to 2004	GEM(Generic Electronic Module)																											
Ford	Escape	From 2004	SYSTEM SEARCH																											
Ford	Escape	From 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	From 2004	PATS(Passive Anti Theft System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	RCM(Restraint Control Module)																											
Ford	Escape	From 2004	IC(Instrument cluster)																											
Ford	Escape	From 2004	GEM(Generic Electronic Module)																											
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Excursion	GASOLINE	SYSTEM SEARCH																											
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																												
Ford	Excursion	GASOLINE	ABS(Anti-Lock Brake System)																												
Ford	Excursion	GASOLINE	CSM(Central Security Module)																												
Ford	Excursion	GASOLINE	DSM(Driver's Seat Module)																												
Ford	Excursion	GASOLINE	EATC(Electronic Automatic Temperature Control)																												
Ford	Excursion	GASOLINE	ECS(Electronic Crash Sensor)																												
Ford	Excursion	GASOLINE	GEM(Generic Electronic Module)																												
Ford	Excursion	GASOLINE	HEC(Hybrid Electrical Cluster)																												
Ford	Excursion	GASOLINE	OTC(Overhead Trip Computer)																												
Ford	Excursion	GASOLINE	PAM(Parking Aid Module)																												
Ford	Excursion	GASOLINE	PATS(Passive Anti Theft System)																												
Ford	Excursion	GASOLINE	TCM(Transmission Control Module)																												
Ford	Excursion	GASOLINE	VSM(Vehicle Security Module)																												
Ford	Excursion	DIESEL	SYSTEM SEARCH																												
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																												
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																												
Ford	Excursion	DIESEL	ABS(Anti-Lock Brake System)																												
Ford	Excursion	DIESEL	CSM(Central Security Module)																												
Ford	Excursion	DIESEL	DSM(Driver's Seat Module)																												
Ford	Excursion	DIESEL	EATC(Electronic Automatic Temperature Control)																												
Ford	Excursion	DIESEL	ECS(Electronic Crash Sensor)																												
Ford	Excursion	DIESEL	GEM(Generic Electronic Module)																												
Ford	Excursion	DIESEL	HEC(Hybrid Electrical Cluster)																												
Ford	Excursion	DIESEL	OTC(Overhead Trip Computer)																												
Ford	Excursion	DIESEL	PAM(Parking Aid Module)																												
Ford	Excursion	DIESEL	PATS(Passive Anti Theft System)																												
Ford	Excursion	DIESEL	TCM(Transmission Control Module)																												
Ford	Excursion	DIESEL	VSM(Vehicle Security Module)																												
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	APIM(Accessory Protocol Interface Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DCSM(Driver-Dual Climate Control Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	EATC(Electronic Automatic Temperature Control)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VSM(Vehicle Security Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	LTM(Liftgate/Trunk Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PRB(Power Running Board)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCU(Audio Rear Control Unit)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RETM(Rear Entertainment Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SDARS(Satellite Digital Audio Receiver System)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TBC(Trailer Brake Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCCM(Transfer Case Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCM(Transmission Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	4X4(4x4 Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PATS(Passive Anti Theft System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	SYSTEM SEARCH																											
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																											
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																											
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																											
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																											
Ford	ExpeditionExpedition EL	5.4L	2V	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	ExpeditionExpedition EL	5.4L	2V	DSM(Driver's Seat Module)																											
Ford	ExpeditionExpedition EL	5.4L	2V	GEM(Generic Electronic Module)																											
Ford	ExpeditionExpedition EL	5.4L	2V	EATC(Electronic Automatic Temperature Control)																											
Ford	ExpeditionExpedition EL	5.4L	2V	IC(Instrument Cluster)																											
Ford	ExpeditionExpedition EL	5.4L	2V	PAM(Parking Aid Module)																											
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																											
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																											
Ford	ExpeditionExpedition EL	5.4L	2V	VDM(Vehicle Dynamic Module)																											
Ford	ExpeditionExpedition EL	5.4L	2V	RIM(Remote Immobilizer Module)																											
Ford	ExpeditionExpedition EL	5.4L	2V	VSM(Vehicle Security Module)																											
Ford	ExpeditionExpedition EL	4.6L	2V	SYSTEM SEARCH																											
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																											
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	APIM(Accessory Protocol Interface Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GPSM(Global Positioning System Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	4.6L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PRB(Power Running Board)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCU(Audio Rear Control Unit)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RETM(Rear Entertainment Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	TCM(Transmission Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	4X4(4x4 Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VSM(Vehicle Security Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2015 MY	3.5L	TiVCT	CLM(Column Lock Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	HUD(Head Up Display)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2014 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Explorer	2013 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Explorer	2013 MY	3.5L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2012 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	ACM(Audio Control Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	BCM(Body Control Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	CLM(Column Lock Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	HUD(Head Up Display)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Explorer	2012 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																										
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																										
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	HUD(Head Up Display)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Explorer	2011 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Explorer	2010 MY	4.0L	2V	SYSTEM SEARCH																										
Ford	Explorer	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																										
Ford	Explorer	2010 MY	4.0L	2V	TCM(Transmission Control Module)																										
Ford	Explorer	2010 MY	4.0L	2V	4X4(4x4 Control Module)																										
Ford	Explorer	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																										
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																										
Ford	Explorer	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																										
Ford	Explorer	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																										
Ford	Explorer	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Explorer	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																										
Ford	Explorer	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Explorer	2010 MY	4.0L	2V	IC(Instrument Cluster)																										
Ford	Explorer	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																										
Ford	Explorer	2010 MY	4.0L	2V	PAM(Parking Aid Module)																										
Ford	Explorer	2010 MY	4.0L	2V	PRB(Power Running Board)																										
Ford	Explorer	2010 MY	4.0L	2V	RCM(Restraint Control Module)																										
Ford	Explorer	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																										
Ford	Explorer	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Explorer	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																										
Ford	Explorer	2010 MY	4.6L	3V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Explorer	2010 MY	4.6L	3V	TCM(Transmission Control Module)																										
Ford	Explorer	2010 MY	4.6L	3V	4X4(4x4 Control Module)																										
Ford	Explorer	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2010 MY	4.6L	3V	ACM(Audio Control Module)																										
Ford	Explorer	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Explorer	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																										
Ford	Explorer	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Explorer	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																										
Ford	Explorer	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Explorer	2010 MY	4.6L	3V	IC(Instrument Cluster)																										
Ford	Explorer	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																										
Ford	Explorer	2010 MY	4.6L	3V	PAM(Parking Aid Module)																										
Ford	Explorer	2010 MY	4.6L	3V	PRB(Power Running Board)																										
Ford	Explorer	2010 MY	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Explorer	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																										
Ford	Explorer	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Explorer	2009 MY	4.0L	2V	SYSTEM SEARCH																										
Ford	Explorer	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																										
Ford	Explorer	2009 MY	4.0L	2V	TCM(Transmission Control Module)																										
Ford	Explorer	2009 MY	4.0L	2V	4X4(4x4 Control Module)																										
Ford	Explorer	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																										
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																										
Ford	Explorer	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																										
Ford	Explorer	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																										
Ford	Explorer	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Explorer	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																										
Ford	Explorer	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Explorer	2009 MY	4.0L	2V	IC(Instrument Cluster)																										
Ford	Explorer	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																										
Ford	Explorer	2009 MY	4.0L	2V	PAM(Parking Aid Module)																										
Ford	Explorer	2009 MY	4.0L	2V	PRB(Power Running Board)																										
Ford	Explorer	2009 MY	4.0L	2V	RCM(Restraint Control Module)																										
Ford	Explorer	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																										
Ford	Explorer	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Explorer	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																										
Ford	Explorer	2009 MY	4.6L	3V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Explorer	2009 MY	4.6L	3V	TCM(Transmission Control Module)																										
Ford	Explorer	2009 MY	4.6L	3V	4X4(4x4 Control Module)																										
Ford	Explorer	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2009 MY	4.6L	3V	ACM(Audio Control Module)																										
Ford	Explorer	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Explorer	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																										
Ford	Explorer	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Explorer	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																										
Ford	Explorer	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Explorer	2009 MY	4.6L	3V	IC(Instrument Cluster)																										
Ford	Explorer	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																										
Ford	Explorer	2009 MY	4.6L	3V	PAM(Parking Aid Module)																										
Ford	Explorer	2009 MY	4.6L	3V	PRB(Power Running Board)																										
Ford	Explorer	2009 MY	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Explorer	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																										
Ford	Explorer	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Explorer	2008 MY	4.0L	2V	SYSTEM SEARCH																										
Ford	Explorer	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																										
Ford	Explorer	2008 MY	4.0L	2V	TCM(Transmission Control Module)																										
Ford	Explorer	2008 MY	4.0L	2V	4X4(4x4 Control Module)																										
Ford	Explorer	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2008 MY	4.0L	2V	ACM(Audio Control Module)																										
Ford	Explorer	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																										
Ford	Explorer	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	Explorer	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																										
Ford	Explorer	2008 MY	4.0L	2V	IC(Instrument Cluster)																										
Ford	Explorer	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																										
Ford	Explorer	2008 MY	4.0L	2V	PAM(Parking Aid Module)																										
Ford	Explorer	2008 MY	4.0L	2V	PRB(Power Running Board)																										
Ford	Explorer	2008 MY	4.0L	2V	RCM(Restraint Control Module)																										
Ford	Explorer	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																										
Ford	Explorer	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Explorer	2008 MY	4.6L	3V	SYSTEM SEARCH																										
Ford	Explorer	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Explorer	2008 MY	4.6L	3V	TCM(Transmission Control Module)																										
Ford	Explorer	2008 MY	4.6L	3V	4X4(4x4 Control Module)																										
Ford	Explorer	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2007 MY	4.6L	3V	PAM(Parking Aid Module)																										
Ford	Explorer	2007 MY	4.6L	3V	PRB(Power Running Board)																										
Ford	Explorer	2007 MY	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Explorer	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																										
Ford	Explorer	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Explorer	2006 MY	4.0L	2V	SYSTEM SEARCH																										
Ford	Explorer	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																										
Ford	Explorer	2006 MY	4.0L	2V	TCM(Transmission Control Module)																										
Ford	Explorer	2006 MY	4.0L	2V	4X4(4x4 Control Module)																										
Ford	Explorer	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2006 MY	4.0L	2V	ACM(Audio Control Module)																										
Ford	Explorer	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																										
Ford	Explorer	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	Explorer	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																										
Ford	Explorer	2006 MY	4.0L	2V	IC(Instrument Cluster)																										
Ford	Explorer	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																										
Ford	Explorer	2006 MY	4.0L	2V	PAM(Parking Aid Module)																										
Ford	Explorer	2006 MY	4.0L	2V	PRB(Power Running Board)																										
Ford	Explorer	2006 MY	4.0L	2V	RCM(Restraint Control Module)																										
Ford	Explorer	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																										
Ford	Explorer	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Explorer	2006 MY	4.6L	3V	SYSTEM SEARCH																										
Ford	Explorer	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Explorer	2006 MY	4.6L	3V	TCM(Transmission Control Module)																										
Ford	Explorer	2006 MY	4.6L	3V	4X4(4x4 Control Module)																										
Ford	Explorer	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2006 MY	4.6L	3V	ACM(Audio Control Module)																										
Ford	Explorer	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																										
Ford	Explorer	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																										
Ford	Explorer	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																										
Ford	Explorer	2006 MY	4.6L	3V	IC(Instrument Cluster)																										
Ford	Explorer	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																										
Ford	Explorer	2006 MY	4.6L	3V	PAM(Parking Aid Module)																										
Ford	Explorer	2006 MY	4.6L	3V	PRB(Power Running Board)																										
Ford	Explorer	2006 MY	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Explorer	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																										
Ford	Explorer	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Explorer	2005 MY	SYSTEM SEARCH																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																												
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																												
Ford	Explorer	2005 MY	ABS(Anti-Lock Brake System)																												
Ford	Explorer	2005 MY	PAM(Parking Aid Module)																												
Ford	Explorer	2005 MY	4X4(4x4 Control Module)																												
Ford	Explorer	2005 MY	HEC(Hybrid Electrical Cluster)																												
Ford	Explorer	2005 MY	RCM(Restraint Control Module)																												
Ford	Explorer	2005 MY	VSM(Vehicle Security Module)																												
Ford	Explorer	2004 MY	SYSTEM SEARCH																												
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																												
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																												
Ford	Explorer	2004 MY	ABS(Anti-Lock Brake System)																												
Ford	Explorer	2004 MY	PAM(Parking Aid Module)																												
Ford	Explorer	2004 MY	4X4(4x4 Control Module)																												
Ford	Explorer	2004 MY	HEC(Hybrid Electrical Cluster)																												
Ford	Explorer	2004 MY	RCM(Restraint Control Module)																												
Ford	Explorer	2004 MY	VSM(Vehicle Security Module)																												
Ford	Explorer	2003 MY	SYSTEM SEARCH																												
Ford	Explorer	2003 MY	PCM(PowerTrain Control Module)																												
Ford	Explorer	2003 MY	ABS(Anti-Lock Brake System)																												
Ford	Explorer	2003 MY	PAM(Parking Aid Module)																												
Ford	Explorer	2003 MY	4X4(4x4 Control Module)																												
Ford	Explorer	2003 MY	HEC(Hybrid Electrical Cluster)																												
Ford	Explorer	2003 MY	RCM(Restraint Control Module)																												
Ford	Explorer	2003 MY	VSM(Vehicle Security Module)																												
Ford	Explorer	2002 MY	SYSTEM SEARCH																												
Ford	Explorer	2002 MY	PCM(PowerTrain Control Module)																												
Ford	Explorer	2002 MY	ABS(Anti-Lock Brake System)																												
Ford	Explorer	2002 MY	PAM(Parking Aid Module)																												
Ford	Explorer	2002 MY	4X4(4x4 Control Module)																												
Ford	Explorer	2002 MY	HEC(Hybrid Electrical Cluster)																												
Ford	Explorer	2002 MY	RCM(Restraint Control Module)																												
Ford	Explorer	2002 MY	VSM(Vehicle Security Module)																												
Ford	Explorer	2001 MY	SYSTEM SEARCH																												
Ford	Explorer	2001 MY	PCM(PowerTrain Control Module)																												
Ford	Explorer	2001 MY	ABS(Anti-Lock Brake System)																												
Ford	Explorer	2001 MY	RCM(Restraint Control Module)																												
Ford	Explorer	2001 MY	RIM(Remote Immobilizer Module)																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer	2001 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2001 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	SYSTEM SEARCH																											
Ford	Explorer	2000 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2000 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2000 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	2000 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2000 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	1999 MY	SYSTEM SEARCH																											
Ford	Explorer	1999 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1999 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1999 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1999 MY	PAM(Parking Aid Module)																											
Ford	Explorer	1998 MY	SYSTEM SEARCH																											
Ford	Explorer	1998 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1998 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1998 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1998 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1997 MY	SYSTEM SEARCH																											
Ford	Explorer	1997 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1997 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1997 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1997 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer SportTrac	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer SportTrac	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer SportTrac	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ACM(Audio Control Module)																										
Ford	Explorer SportTrac	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																										
Ford	Explorer SportTrac	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																										
Ford	Explorer SportTrac	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																										
Ford	Explorer SportTrac	2006 MY	4.6L	3V	IC(Instrument Cluster)																										
Ford	Explorer SportTrac	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																										
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PAM(Parking Aid Module)																										
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PRB(Power Running Board)																										
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																										
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	E-Series	5.4L	2V	2004 ~	SYSTEM SEARCH																										
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																										
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																										
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																										
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																										
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																										
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																										
Ford	E-Series	5.4L	2V	2004 ~	RAP(Remote Anti-Theft/Personality Module)																										
Ford	E-Series	5.4L	2V	2004 ~	RCM(Restraint Control Module)																										
Ford	E-Series	5.4L	2V	2004 ~	PAM(Parking Aid Module)																										
Ford	E-Series	5.4L	2V	2004 ~	VSM(Vehicle Security Module)																										
Ford	E-Series	5.4L	2V	2009 ~	SYSTEM SEARCH																										
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																										
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																										
Ford	E-Series	5.4L	2V	2009 ~	ABS(Anti-Lock Brake System)																										
Ford	E-Series	5.4L	2V	2009 ~	ACM(Audio Control Module)																										
Ford	E-Series	5.4L	2V	2009 ~	APIM(Accessory Protocol Interface Module)																										
Ford	E-Series	5.4L	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	E-Series	5.4L	2V	2009 ~	GPSM(Global Positioning System Module)																										
Ford	E-Series	5.4L	2V	2009 ~	IPC(Instrument Panel Control Module)																										
Ford	E-Series	5.4L	2V	2009 ~	PAM(Parking Aid Module)																										
Ford	E-Series	5.4L	2V	2009 ~	RCM(Restraint Control Module)																										
Ford	E-Series	5.4L	2V	2009 ~	SDARS(Satellite Digital Audio Receiver System)																										
Ford	E-Series	5.4L	2V	2009 ~	TBC(Trailer Brake Control Module)																										
Ford	E-Series	5.4L	2V	2009 ~	TCM(Transmission Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																											
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																											
Ford	F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																											
Ford	F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																											
Ford	F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																											
Ford	F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																											
Ford	F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																											
Ford	F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																											
Ford	F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																											
Ford	F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																											
Ford	F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																											
Ford	F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																											
Ford	F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																											
Ford	F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																											
Ford	F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																											
Ford	F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																											
Ford	F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																											
Ford	F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																											
Ford	F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																											
Ford	F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																											
Ford	F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																											
Ford	F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																											
Ford	F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																											
Ford	F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																										
Ford	F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																										
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																										
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																										
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																									
Ford	F150	4.6L(BETA)	3V	SYSTEM SEARCH																										
Ford	F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																										
Ford	F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																										
Ford	F150	4.6L(BETA)	3V	ACM(Audio Control Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																										
Ford	F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																										
Ford	F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																										
Ford	F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	4.6L(BETA)	3V	IC(Instrument Cluster)																										
Ford	F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																										
Ford	F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																										
Ford	F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																										
Ford	F150	4.6L(BETA)	3V	PRB(Power Running Board)																										
Ford	F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																										
Ford	F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																										
Ford	F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																										
Ford	F150	5.0L	TiVCT	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	F150	5.0L	TiVCT	PCM(Powertrain Control Module)																											
Ford	F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																											
Ford	F150	5.0L	TiVCT	ACM(Audio Control Module)																											
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																											
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																											
Ford	F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	F150	5.0L	TiVCT	DSM(Driver's Seat Module)																											
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																											
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																											
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																											
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																											
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																											
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																											
Ford	F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																											
Ford	F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																											
Ford	F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																											
Ford	F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F150	5.0L	TiVCT	IC(Instrument Cluster)																											
Ford	F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																											
Ford	F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																											
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																											
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																											
Ford	F150	5.0L	TiVCT	PRB(Power Running Board)																											
Ford	F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																											
Ford	F150	5.0L	TiVCT	RCM(Restraint Control Module)																											
Ford	F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																											
Ford	F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																											
Ford	F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																											
Ford	F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																											
Ford	F150	5.0L	TiVCT	TCM(Transmission Control Module)																											
Ford	F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																											
Ford	F150	5.4L	3V	2009 ~	SYSTEM SEARCH																										
Ford	F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																										
Ford	F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																										
Ford	F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																										
Ford	F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																										
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																										
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																										
Ford	F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																										
Ford	F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																										
Ford	F150	5.4L	3V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																										
Ford	F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																										
Ford	F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																										
Ford	F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																										
Ford	F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																										
Ford	F150	5.4L	3V	2009 ~	PRB(Power Running Board)																										
Ford	F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																										
Ford	F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																										
Ford	F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																										
Ford	F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																										
Ford	F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																										
Ford	F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																										
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																										
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																										
Ford	F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																										
Ford	F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																										
Ford	F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																										
Ford	F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																										
Ford	F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																										
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																										
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																										
Ford	F150	6.2L(BETA)	2V	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																											
Ford	F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																											
Ford	F150	6.2L(BETA)	2V	ACM(Audio Control Module)																											
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																											
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																											
Ford	F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																											
Ford	F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																											
Ford	F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																											
Ford	F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																											
Ford	F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																											
Ford	F150	6.2L(BETA)	2V	IC(Instrument Cluster)																											
Ford	F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																											
Ford	F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																											
Ford	F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																											
Ford	F150	6.2L(BETA)	2V	PRB(Power Running Board)																											
Ford	F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																											
Ford	F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																											
Ford	F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																											
Ford	F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																											
Ford	F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																											
Ford	F150	Other	2004 ~ 2008	SYSTEM SEARCH																											
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																											
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																											
Ford	F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																											
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																											
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																											
Ford	F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																											
Ford	F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																											
Ford	F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																											
Ford	F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F150	Other	2004 ~ 2008	IC(Instrument Cluster)																											
Ford	F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																											
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																											
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																											
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																											
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																											
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										
Ford	F250	7.3L	SYSTEM SEARCH																											
Ford	F250	7.3L	PCM(PowerTrain Control Module)																											
Ford	F250	7.3L	ABS(Anti-Lock Brake System)																											
Ford	F250	7.3L	ECS(Electronic Crash Sensor)																											
Ford	F250	7.3L	GEM(Generic Electronic Module)																											
Ford	F250	6.2L	SYSTEM SEARCH																											
Ford	F250	6.2L	PCM(Powertrain Control Module)																											
Ford	F250	6.2L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.2L	ACM(Audio Control Module)																											
Ford	F250	6.2L	APIM(Accessory Protocol Control Module)																											
Ford	F250	6.2L	BCMii(Body Control Module)																											
Ford	F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																											
Ford	F250	6.2L	DSM(Driver Seat Module)																											
Ford	F250	6.2L	GPSM(Global Positioning System Module)																											
Ford	F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F250	6.2L	IPC(Instrument Panel Control Module)																											
Ford	F250	6.2L	PAM(Parking Aid Module)																											
Ford	F250	6.2L	RCM(Restraint Control Module)																											
Ford	F250	6.2L	SCCM(Streering Colume Control Module)																											
Ford	F250	6.2L	TBC(Trailer Brake Control Module)																											
Ford	F250	6.2L	TCCM(Transfer Case Control Module)																											
Ford	F250	6.2L	TPM(Tire Pressure Monitor)																											
Ford	F250	6.0L	SYSTEM SEARCH																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.0L	GEM(Generic Electronic Module)																											
Ford	F250	6.0L	HEC(Hybrid Electrical Cluster)																											
Ford	F250	6.0L	OTC(Overhead Trip Computer)																											
Ford	F250	6.0L	PAM(Parking Aid Module)																											
Ford	F250	6.0L	PATS(Passive Anti Theft System)																											
Ford	F250	6.0L	RCM(Restraint Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	VSM(Vehicle Security Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SYSTEM SEARCH																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM(PowerTrain Control Module)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4(4x4 Control Module)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS(Anti-Lock Brake System)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM(Audio Control Module)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM(Auxiliary Heater Control Module)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM(Accessory Protocol Interface Module)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM(Circuit Deactivation Ignition Module)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM(Driver's Seat Module)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GPSM(Global Positioning System Module)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC(Instrument Cluster)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM(Parking Aid Module)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM(Restraint Control Module)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM(Rear Entertainment Module)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS(Satellite Digital Audio Receiver System)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC(Trailer Brake Control Module)																											
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM(Transmission Control Module)																											
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																									
Ford	Fiesta	1.4L	DURATEC 16V	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Fiesta	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	1.6L	DURATEC	PSCM(Power Steering Control Module)																											
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																											
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																											
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																											
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																											
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																											
Ford	Fiesta	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																											
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																											
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																											
Ford	Fiesta	1.6L	DURATEC	BCMii(Body Control Module)																											
Ford	Fiesta	1.6L	DURATEC	FCDIM(Front Control/Display Interface Module)																											
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																											
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																											
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																											
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																											
Ford	Fiesta	1.6L	TiVCT	SYSTEM SEARCH																											
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																											
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																											
Ford	Fiesta	1.6L	TiVCT	TCM(Transmission Control Module)																											
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																											
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																											
Ford	Fiesta	1.6L	TiVCT	APIM(Accessory Protocol Interface Module)																											
Ford	Fiesta	1.6L	TiVCT	BCM(Body Control Module)																											
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																											
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																											
Ford	Fiesta	1.6L	TiVCT	GPSM(Global Positioning System Module)																											
Ford	Fiesta	1.6L	TiVCT	IPC(Instrument Panel Control Module)																											
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																											
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																											
Ford	Fiesta	1.6L	TiVCT	PSCM(Power Steering Control Module)																											
Ford	Fiesta	1.6L	TiVCT	RCM(Restraint Control Module)																											
Ford	Fiesta	1.6L	TiVCT	RFA(Remote Function Actuator)																											
Ford	Fiesta	1.6L	TiVCT	VSM(Vehicle Security Module)																											
Ford	Fiesta	1.6L	Zetec Rocam	SYSTEM SEARCH																											
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																											
Ford	Fiesta	1.6L	Zetec Rocam	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	1.6L	Zetec Rocam	IC(Instrument Cluster)																											
Ford	Fiesta	1.6L	Zetec Rocam	RCM(Restraint Control Module)																											
Ford	Fiesta	1.6L	Zetec Rocam	RKE(Remote Keyless Entry)																											
Ford	Fiesta	1.6L	Zetec Rocam	TCM(Transmission Control Module)																											
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	SYSTEM SEARCH																											
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																											
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																											
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																											
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Fiesta	2.0L	SYSTEM SEARCH																												
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																												
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																												
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																												
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																												
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																												
Ford	Fiesta	2.0L	ACM(Audio Control Module)																												
Ford	Fiesta	2.0L	EATC(Electronic Automatic Temperature Control)																												
Ford	Fiesta	2.0L	GEM(Generic Electronic Module)																												
Ford	Fiesta	2.0L	IC(Instrument Cluster)																												
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																												
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																												
Ford	Fiesta	2.0L	RCM(Restraint Control Module)																												
Ford	Fiesta	2.0L	PATS(Passive Anti Theft System)-BETA																												
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																											
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																											
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																											
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																											
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																											
Ford	Focus	1.6L	ZETEC ROCAM	SYSTEM SEARCH																											
Ford	Focus	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																											
Ford	Focus	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																											
Ford	Focus	1.6L	ZETEC ROCAM	EATC(Electronic Automatic Temperature Control)																											
Ford	Focus	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																											
Ford	Focus	1.6L	ZETEC ROCAM	HCM(Headlamp Control Module)																											
Ford	Focus	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Focus	1.6L	ZETEC ROCAM	MC(Message Center)																											
Ford	Focus	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																											
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																											
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)		V	V	V	V																						
Ford	Focus	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	CSM(Central Security Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																											
Ford	Focus	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																											
Ford	Focus	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)						V																					
Ford	Focus	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																											
Ford	Focus	1.6L	DURATEC-HE/I4	EPS(Electronic power steering)																											
Ford	Focus	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)						V																					
Ford	Focus	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	NAV(Navigation System)																											
Ford	Focus	1.6L	DURATEC-HE/I4	HEC(Hybrid Electrical Cluster)																											
Ford	Focus	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																											
Ford	Focus	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)						V																					
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																											
Ford	Focus	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																											
Ford	Focus	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																											
Ford	Focus	1.6L	DURATEC-HE/I4	SRM(Speech recognition module)																											
Ford	Focus	1.6L	DURATEC-HE/I4	MC(Message Center)																											
Ford	Focus	1.6L	DURATEC VCT	SYSTEM SEARCH																											
Ford	Focus	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																											
Ford	Focus	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)							V	V																			
Ford	Focus	1.6L	DURATEC VCT	ACM(Audio Control Module)																											
Ford	Focus	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																											
Ford	Focus	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Focus	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)									V	V																
Ford	Focus	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)											V															
Ford	Focus	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)												V	V	V	V	V	V									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)						V																				
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic power steering)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																		V	V							
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)						V																				
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)						V																				
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																											
Ford	Focus	1.8L	DURATEC HE/I4	SYSTEM SEARCH																											
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																											
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																											
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																											
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																											
Ford	Focus	1.8L	DURATEC HE/I4	ACM(Audio control module)																											
Ford	Focus	1.8L	DURATEC HE/I4	CDP(Compact Disc Player)																											
Ford	Focus	1.8L	DURATEC HE/I4	CSM(Central Security Module)																											
Ford	Focus	1.8L	DURATEC HE/I4	D_DCU(Driver Door Control Unit)						V																					
Ford	Focus	1.8L	DURATEC HE/I4	EATC(Electronic Automatic Temperature Control)																											
Ford	Focus	1.8L	DURATEC HE/I4	EPS(Electronic power steering)																											
Ford	Focus	1.8L	DURATEC HE/I4	GDM(Generic Display Module)																											
Ford	Focus	1.8L	DURATEC HE/I4	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																											
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)						V																					
Ford	Focus	1.8L	DURATEC HE/I4	IC(Instrument cluster)																											
Ford	Focus	1.8L	DURATEC HE/I4	NAV(Navigation System)																											
Ford	Focus	1.8L	DURATEC HE/I4	PAM(Parking Aid Module)																											
Ford	Focus	1.8L	DURATEC HE/I4	PDM(Passenger's Door Module)						V																					
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																											
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																											
Ford	Focus	1.8L	DURATEC HE/I4	RETM(Rear Entertainment Module)																											
Ford	Focus	1.8L	DURATEC HE/I4	RKE(Remote Keyless Entry)																											
Ford	Focus	1.8L	DURATEC HE/I4	SRM(Speech recognition module)																											
Ford	Focus	1.8L	DURATEC HE/I4	HCM(Headlamp Control Module)																											
Ford	Focus	1.8L	DURATEC HE/I4	HEC(Hybrid Electrical Cluster)																											
Ford	Focus	1.8L	DURATEC HE/I4	MC(Message Center)																											
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																											
Ford	Focus	1.8L	DURATEC HE/I4	TCM(Transmission Control Module)																											
Ford	Focus	2.0L DURATEC HE/I4	~2007	SYSTEM SEARCH																											
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																											
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																											
Ford	Focus	2.0L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																											
Ford	Focus	2.0L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																											
Ford	Focus	2.0L DURATEC HE/I4	~2007	IC(Instrument cluster)																											
Ford	Focus	2.0L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	ABS(Anti-Lock Brake System)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	ACM(Audio control module)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	APIM(Accessory Protocol Interface Module)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	FCIM(Front Controls Interface Module)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	FDIM(Front Display Interface Module)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	GPSM(Global Positioning System Module)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	IC(Instrument cluster)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	OCSM(Occupant Classification System Module)																											
Ford	Focus	2.0L DURATEC HE/I4	2008~	RCM(Restraint Control Module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SYSTEM SEARCH																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TCM(Transmission control module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																				V	V	V					
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CDP(Compact Disc Player)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CSM(Central Security Module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	D_DCU(Driver Door Control Unit)						V																					
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EATC(Electronic Automatic Temperature Control)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EPS(Electronic power steering)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GDM(Generic Display Module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)						V																					
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HEC(Hybrid Electrical Cluster)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	IC(Instrument cluster)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	NAV(Navigation System)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PAM(Parking Aid Module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PDM(Passenger's Door Module)						V																					
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RETM(Rear Entertainment Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RKE(Remote Keyless Entry)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TBM(Tracking And Blocking Module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RL_DCU(Rear Left Door Control Unit)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RR_DCU(Rear Right Door Control Unit)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SRM(Speech recognition module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HCM(Headlamp Control Module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																											
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SYSTEM SEARCH																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PCM(PowerTrain Control Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ABS(Anti-Lock Brake System)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ACM(Audio Control Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	APIM(Accessory Protocol Interface Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	BCM(Body Control Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DDM(Driver's Door Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCDIM(Front Control/Display Interface Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	GPSM(Global Positioning System Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	IPC(Instrument Panel Control Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	OCSM(Occupant Classification System Module)																						V					
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PAM(Parking Aid Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PDM(Passenger's Door Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PSCM(Power Steering Control Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RCM(Restraint Control Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SASM(Steering Angle Sensor Module)																											
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	TCM(Transmission Control Module)																											
Ford	Focus	2.0L DIESEL	2003 ~ 2008	SYSTEM SEARCH																											
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PCM(PowerTrain Control Module)													V				V							V	V	V
Ford	Focus	2.0L DIESEL	2003 ~ 2008	ABS(Anti-Lock Brake System)																											
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CDP(Compact Disc Player)																											
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CMR(Camera Module Rear)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Focus	2.0L DIESEL	2003 ~ 2008	D_DCU(Driver Door Control Unit)						V																				
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FACM(Fuel Additive Control Module)																		V	V							
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	GEM(Generic Electronic Module)						V																				
Ford	Focus	2.0L DIESEL	2003 ~ 2008	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PAM(Parking Aid Module)						V																				
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RETM(Rear Entertainment Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RKE(Remote Keyless Entry)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	TCM(Transmission control module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ABS(Anti-Lock Brake System)																				V	V	V				
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	GEM(Generic Electronic Module)						V																				
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	DDM(Driver's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	MC(Message Center)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ACM(Audio control module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)												V	V	V	V	V	V									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)							V																			
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D DCU(Driver Door Control Unit)						V																				
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																		V	V							
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)						V																				
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)						V																				
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)						V																					
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EPS(Electronic Power Steering)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)						V																					
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)						V																					
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	NAV(Navigation System)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SRM(Speech Recognition Module)																											
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	SYSTEM SEARCH																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)							V	V																			
Ford	Focus C-MAX	1.6L	DURATEC VCT	ACM(Audio Control Module)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	BCMii(Body Control Module)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	DDM(Driver's Door Module)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																											
Ford	Focus C-MAX	1.6L	DURATEC VCT	PAM(Parking Aid Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Focus C-MAX	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)									V	V																
Ford	Focus C-MAX	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)											V															
Ford	Focus C-MAX	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)		V	V	V	V																					
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)						V																				
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GEM(Generic Electronic Module)						V																				
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PDM(Passenger's Door Module)						V																				
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)		V	V	V	V																					
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)						V																				
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)						V																				
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PDM(Passenger's Door Module)						V																				
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Flex	3.5L	4V	SYSTEM SEARCH																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	4V	ACM(Audio control module)																										
Ford	Flex	3.5L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	4V	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	4V	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	4V	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	4V	IC(Instrument cluster)																										
Ford	Flex	3.5L	4V	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	4V	LTM(Liftgate/Trunk Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Flex	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	4V	Factory Keyless Entry Code																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio control module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC(Instrument cluster)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Flex	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	TiVCT	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Flex	3.5L	TiVCT	ACM(Audio control module)																											
Ford	Flex	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																											
Ford	Flex	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	Flex	3.5L	TiVCT	DDM(Driver's Door Module)																											
Ford	Flex	3.5L	TiVCT	DSM(Driver's Seat Module)																											
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																											
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																											
Ford	Flex	3.5L	TiVCT	FCIM(Front Controls Interface Module)																											
Ford	Flex	3.5L	TiVCT	FDIM(Front Display Interface Module)																											
Ford	Flex	3.5L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Flex	3.5L	TiVCT	GPSM(Global Positioning System Module)																											
Ford	Flex	3.5L	TiVCT	HCM(Headlamp Control Module)																											
Ford	Flex	3.5L	TiVCT	HCM-2(Headlamp Control Module2)																											
Ford	Flex	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Flex	3.5L	TiVCT	IC(Instrument cluster)																											
Ford	Flex	3.5L	TiVCT	ILCM(Interior Lighting Control Module)																											
Ford	Flex	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																											
Ford	Flex	3.5L	TiVCT	OCSM(Occupant Classification System Module)																											
Ford	Flex	3.5L	TiVCT	PAM(Parking Aid Module)																											
Ford	Flex	3.5L	TiVCT	PSCM(Power Steering Control Module)																											
Ford	Flex	3.5L	TiVCT	RCM(Restraint Control Module)																											
Ford	Flex	3.5L	TiVCT	RETM(Rear Entertainment Module)																											
Ford	Flex	3.5L	TiVCT	SASM(Steering Angle Sensor Module)																											
Ford	FreestarMonterey	3.9L	SYSTEM SEARCH																												
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																												
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																												
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																												
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																												
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																												
Ford	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																												
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																												
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																												
Ford	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																												
Ford	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																												
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																												
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																												
Ford	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																												
Ford	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																												
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																												
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																												
Ford	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																												
Ford	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																												
Ford	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																												
Ford	FreestarMonterey	4.2L	SYSTEM SEARCH																												
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																												
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																												
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																												
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																												
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																												
Ford	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																												
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																												
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																												
Ford	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																												
Ford	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																												
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																												
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																												
Ford	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																												
Ford	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																												
Ford	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																												
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																												
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																												
Ford	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																												
Ford	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																												
Ford	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																												
Ford	Freestyle	3.0L	4V	SYSTEM SEARCH																											
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																											
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																											
Ford	Freestyle	3.0L	4V	4X4(4x4 Control Module)																											
Ford	Freestyle	3.0L	4V	ABS(Anti-Lock Brake System)																											
Ford	Freestyle	3.0L	4V	ACM(Audio Control Module)																											
Ford	Freestyle	3.0L	4V	DSM(Driver's Seat Module)																											
Ford	Freestyle	3.0L	4V	EATC(Electronic Automatic Temperature Control)																											
Ford	Freestyle	3.0L	4V	GEM(Generic Electronic Module)																											
Ford	Freestyle	3.0L	4V	IC(Instrument Cluster)																											
Ford	Freestyle	3.0L	4V	PAM(Parking Aid Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Freestyle	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Freestyle	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Five Hundred	3.0L	4V	SYSTEM SEARCH																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Five Hundred	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Five Hundred	3.0L	4V	ACM(Audio Control Module)																										
Ford	Five Hundred	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Five Hundred	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Five Hundred	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Five Hundred	3.0L	4V	IC(Instrument Cluster)																										
Ford	Five Hundred	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Five Hundred	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Five Hundred	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Ford GT	5.4L	4V	SYSTEM SEARCH																										
Ford	Ford GT	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	IC(Instrument Cluster)																										
Ford	Ford GT	5.4L	4V	PATS(Passive Anti Theft System)																										
Ford	Ford GT	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	TCM(Transmission control module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Fusion	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	DURATEC	IC(Instrument cluster)																										
Ford	Fusion	1.6L	DURATEC	ACM(Audio control module)																										
Ford	Fusion	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fusion	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																											
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																											
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																											
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																											
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																											
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																											
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																											
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																											
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																											
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SYSTEM SEARCH																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACM(Audio Control Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BCM(Body Control Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	C-CM(Cruise Control Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DDM(Driver's Door Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSM(Driver's Seat Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GFM(Generic Function Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GWM(Gateway Module A)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HUD(Head Up Display)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PAM(Parking Aid Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PDM(Passenger's Door Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RCM(Restraint Control Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM(Secondary OBD Control Module A)																											
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	TCU(Telematic Control Unit Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																											
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	PAM(Parking Aid Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																											
Ford	Fusion	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																											
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Fusion	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Fusion	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																											
Ford	Fusion	2.5L	IVCT	SYSTEM SEARCH																											
Ford	Fusion	2.5L	IVCT	PCM(PowerTrain Control Module)																											
Ford	Fusion	2.5L	IVCT	ABS(Anti-Lock Brake System)																											
Ford	Fusion	2.5L	IVCT	ACM(Audio Control Module)																											
Ford	Fusion	2.5L	IVCT	APIM(Accessory Protocol Interface Module)																											
Ford	Fusion	2.5L	IVCT	BCM(Body Control Module)																											
Ford	Fusion	2.5L	IVCT	C-CM(Cruise Control Module)																											
Ford	Fusion	2.5L	IVCT	DACM-C(Digital Audio Control Module C)																											
Ford	Fusion	2.5L	IVCT	DDM(Driver's Door Module)																											
Ford	Fusion	2.5L	IVCT	DSM(Driver's Seat Module)																											
Ford	Fusion	2.5L	IVCT	DSP(Digital Signal Processing Module)																											
Ford	Fusion	2.5L	IVCT	FCDIM(Front Control/Display Interface Module)																											
Ford	Fusion	2.5L	IVCT	FCIM(Front Controls Interface Module)																											
Ford	Fusion	2.5L	IVCT	GPSM(Global Positioning System Module)																											
Ford	Fusion	2.5L	IVCT	GWM(Gateway Module A)																											
Ford	Fusion	2.5L	IVCT	HUD(Head Up Display)																											
Ford	Fusion	2.5L	IVCT	IPC(Instrument Panel Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Fusion	2.5L	IVCT	IPM-A(Image Processing Module A)																											
Ford	Fusion	2.5L	IVCT	OCSM(Occupant Classification System Module)																											
Ford	Fusion	2.5L	IVCT	PAM(Parking Aid Module)																											
Ford	Fusion	2.5L	IVCT	PDM(Passenger's Door Module)																											
Ford	Fusion	2.5L	IVCT	PSCM(Power Steering Control Module)																											
Ford	Fusion	2.5L	IVCT	RACM(Rear Audio Control Module)																											
Ford	Fusion	2.5L	IVCT	RCM(Restraint Control Module)																											
Ford	Fusion	2.5L	IVCT	RTM(Radio Transceiver Module)																											
Ford	Fusion	2.5L	IVCT	SCCM(Steering Column Control Module)																											
Ford	Fusion	2.5L	IVCT	SCM-E(Seat Control Module E)																											
Ford	Fusion	2.5L	IVCT	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Fusion	2.5L	IVCT	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																											
Ford	Fusion	3.0L	4V	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																											
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																											
Ford	Fusion	3.0L	4V	4X4(4x4 Control Module)																											
Ford	Fusion	3.0L	4V	ABS(Anti-Lock Brake System)																											
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																											
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																											
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																											
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																											
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																											
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																											
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																											
Ford	Fusion	3.0L	4V	FDIM(Front Display Interface Module)																											
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Fusion	3.0L	4V	GPSM(Global Positioning System Module)																											
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																											
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																											
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																											
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																											
Ford	Fusion	3.0L	4V	PAM(Parking Aid Module)																											
Ford	Fusion	3.0L	4V	PSCM(Power Steering Control Module)																											
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																											
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																											
Ford	Fusion	3.0L	4V	TCM(Transmission Control Module)																											
Ford	Fusion	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Fusion	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Fusion	3.0L	4V	TBM(Tracking And Blocking Module)																											
Ford	Fusion	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																											
Ford	Fusion	3.0L	4V	PATS(Passive Anti Theft System)																											
Ford	Fusion	3.5L	4V	SYSTEM SEARCH																											
Ford	Fusion	3.5L	4V	PCM(PowerTrain Control Module)																											
Ford	Fusion	3.5L	4V	TCM(Transmission Control Module)																											
Ford	Fusion	3.5L	4V	4X4(4x4 Control Module)																											
Ford	Fusion	3.5L	4V	ABS(Anti-Lock Brake System)																											
Ford	Fusion	3.5L	4V	ACM(Audio Control Module)																											
Ford	Fusion	3.5L	4V	APIM(Accessory Protocol Interface Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																											
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																											
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																											
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																											
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																											
Ford	Fusion	3.5L	4V	FDIM(Front Display Interface Module)																											
Ford	Fusion	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Fusion	3.5L	4V	GPSM(Global Positioning System Module)																											
Ford	Fusion	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Fusion	3.5L	4V	IPC(Instrument Panel Control Module)																											
Ford	Fusion	3.5L	4V	OCSM(Occupant Classification System Module)																											
Ford	Fusion	3.5L	4V	PAM(Parking Aid Module)																											
Ford	Fusion	3.5L	4V	PSCM(Power Steering Control Module)																											
Ford	Fusion	3.5L	4V	RCM(Restraint Control Module)																											
Ford	Fusion	3.5L	4V	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Fusion	3.5L	4V	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Fusion	3.5L	4V	TBM(Tracking And Blocking Module)																											
Ford	KA	2000 MY	SYSTEM SEARCH																												
Ford	KA	2000 MY	PCM(PowerTrain Control Module)																												
Ford	KA	2000 MY	ABS(Anti-Lock Brake System)																												
Ford	KA	2000 MY	RCM(Restraint Control Module)																												
Ford	KA	1999 MY	PCM(PowerTrain Control Module)																												
Ford	KA	1999 MY	ABS(Anti-Lock Brake System)																												
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																											
Ford	Kuga	2.0L DIESEL	SYSTEM SEARCH																												
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)														V				V							V			
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																									V			V
Ford	Kuga	2.0L DIESEL	TCM(Transmission Control Module)																												
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)			V	V	V	V																						
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																												
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																												
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																												
Ford	Kuga	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																												
Ford	Kuga	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																												
Ford	Kuga	2.0L DIESEL	AWD(All Wheel Drive Module)																												
Ford	Kuga	2.0L DIESEL	BCMii(Body Control Module)																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Kuga	2.0L DIESEL	CCMii(Cruise Control Module)																											
Ford	Kuga	2.0L DIESEL	CMR(Camera Module Rear)																											
Ford	Kuga	2.0L DIESEL	D_DCU(Driver Door Control Unit)							V																				
Ford	Kuga	2.0L DIESEL	DDM(Driver's Door Module)																											
Ford	Kuga	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Kuga	2.0L DIESEL	EPS(Electronic Power Steering)																											
Ford	Kuga	2.0L DIESEL	FDSM(Front Distance Sensing Module)																											
Ford	Kuga	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																											
Ford	Kuga	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Kuga	2.0L DIESEL	GEM(Generic Electronic Module)							V																				
Ford	Kuga	2.0L DIESEL	GPSM(Global Positioning System Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Kuga	2.0L DIESEL	IPM-A(Image Processing Module A)																											
Ford	Kuga	2.0L DIESEL	IPM-B(Image Processing Module B)																											
Ford	Kuga	2.0L DIESEL	IPC(Instrument Panel Control Module)																											
Ford	Kuga	2.0L DIESEL	IC(Instrument Cluster)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PSCM(Power Steering Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RFA(Remote Function Actuator)																											
Ford	Kuga	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																											
Ford	Kuga	2.0L DIESEL	RETM(Rear Entertainment Module)																											
Ford	Kuga	2.0L DIESEL	SASM(Steering Angle Sensor Module)																											
Ford	Kuga	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Kuga	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Kuga	2.0L DIESEL	SRM(Speech Recognition Module)																											
Ford	Kuga	2.0L DIESEL	TRM(Trailer Module)																											
Ford	Kuga	2.5L	I5	SYSTEM SEARCH																										
Ford	Kuga	2.5L	I5	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.5L	I5	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.5L	I5	ACM(Audio Control Module)																										
Ford	Kuga	2.5L	I5	AWD(All Wheel Drive Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Kuga	2.5L	I5	CMR(Camera Module Rear)																										
Ford	Kuga	2.5L	I5	D_DCU(Driver Door Control Unit)						V																				
Ford	Kuga	2.5L	I5	EATC(Electronic Automatic Temperature Control)																										
Ford	Kuga	2.5L	I5	EPS(Electronic Power Steering)																										
Ford	Kuga	2.5L	I5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Kuga	2.5L	I5	GEM(Generic Electronic Module)						V																				
Ford	Kuga	2.5L	I5	HCM(Headlamp Control Module)																										
Ford	Kuga	2.5L	I5	IC(Instrument Cluster)																										
Ford	Kuga	2.5L	I5	PAM(Parking Aid Module)																										
Ford	Kuga	2.5L	I5	PDM(Passenger's Door Module)																										
Ford	Kuga	2.5L	I5	RCM(Restraint Control Module)																										
Ford	Kuga	2.5L	I5	RETM(Rear Entertainment Module)																										
Ford	Kuga	2.5L	I5	RKE(Remote Keyless Entry)																										
Ford	Kuga	2.5L	I5	SRM(Speech Recognition Module)																										
Ford	Kuga	2.5L	I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																V	V							V		
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Mondeo	2010 MY	2.5L I5	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.5L I5	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.5L I5	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.5L I5	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.5L I5	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.5L I5	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.5L I5	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.5L I5	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SYSTEM SEARCH																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	AHCM(Auxiliary Heater Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	BCMii(Body Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CCMii(Cruise Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DDM(Driver's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DSM(Driver's Seat Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HCM(HeadLamp Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RFA(Remote Function Actuator)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TRM(Trailer Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ACM(Audio Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	CDP(Compact Disc Player)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GDM(Generic Display Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	NAV(Navigation System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SRM(Speech Recognition Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	SYSTEM SEARCH																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	GEM(Generic Electronic Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	HCM(Headlamp Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2000 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	2000 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	2000 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1999 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1999 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Mondeo	1998 MY	1.8L	PCM(PowerTrain Control Module)																											
Ford	Mondeo	1998 MY	1.8L	ABS(Anti-Lock Brake System)																											
Ford	Mondeo	1998 MY	1.8L	CSM(Central Security Module)																											
Ford	Mondeo	1998 MY	1.8L	PATS(Passive Anti Theft System)																											
Ford	Mondeo	1998 MY	1.8L	RIM(Remote Immobilizer Module)																											
Ford	Mondeo	1998 MY	2.0L	SYSTEM SEARCH																											
Ford	Mondeo	1998 MY	2.0L	PCM(PowerTrain Control Module)																											
Ford	Mondeo	1998 MY	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Mondeo	1998 MY	2.0L	CSM(Central Security Module)																											
Ford	Mondeo	1998 MY	2.5L	SYSTEM SEARCH																											
Ford	Mondeo	1998 MY	2.5L	PCM(PowerTrain Control Module)																											
Ford	Mondeo	1998 MY	2.5L	ABS(Anti-Lock Brake System)																											
Ford	Mondeo	1998 MY	2.5L	CSM(Central Security Module)																											
Ford	Mondeo	1997 MY	1.8L	SYSTEM SEARCH																											
Ford	Mondeo	1997 MY	1.8L	PCM(PowerTrain Control Module)																											
Ford	Mondeo	1997 MY	1.8L	ABS(Anti-Lock Brake System)																											
Ford	Mondeo	1997 MY	1.8L	PATS(Passive Anti Theft System)																											
Ford	Mondeo	1997 MY	1.8L	RIM(Remote Immobilizer Module)																											
Ford	Mondeo	1997 MY	2.0L	PCM(PowerTrain Control Module)																											
Ford	Mondeo	1997 MY	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Mondeo	1997 MY	2.5L	PCM(PowerTrain Control Module)																											
Ford	Mondeo	1997 MY	2.5L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.7L	TiVCT	SYSTEM SEARCH																											
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																											
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																											
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																											
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																											
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																											
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																											
Ford	Mustang	3.7L	TiVCT	BCM-B(Body Control Module B)																											
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																											
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																											
Ford	Mustang	3.7L	TiVCT	FDIM(Front Display Interface Module)																											
Ford	Mustang	3.7L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Mustang	3.7L	TiVCT	GPSM(Global Positioning System Module)																											
Ford	Mustang	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Mustang	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Mustang	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Mustang	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Mustang	3.7L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.8L	SYSTEM SEARCH																											
Ford	Mustang	3.8L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.8L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.8L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.8L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.8L	RCM(Restraint Control Module)																											
Ford	Mustang	3.9L	SYSTEM SEARCH																											
Ford	Mustang	3.9L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.9L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.9L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.9L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.9L	RCM(Restraint Control Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	BCM-B(Body Control Module B)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.0L	V6 (SOHC)	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.0L	V6 (SOHC)	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Mustang	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Mustang	4.0L	V6 (SOHC)	PAM(Parking Aid Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	PSCM(Power Steering Control Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																											
Ford	Mustang	4.0L	V6 (SOHC)	PATS(Passive Anti Theft System)-BETA																											
Ford	Mustang	4.6L	3V	SYSTEM SEARCH																											
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																											
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																											
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																											
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																											
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																											
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																											
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																											
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																											
Ford	Mustang	4.6L	3V	BCM-B(Body Control Module B)																											
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																											
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																											
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																											
Ford	Mustang	4.6L	3V	FDIM(Front Display Interface Module)																											
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Mustang	4.6L	3V	GPSM(Global Positioning System Module)																											
Ford	Mustang	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																											
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																											
Ford	Mustang	4.6L	3V	OCSM(Occupant Classification System Module)																											
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																											
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																											
Ford	Mustang	4.6L	3V	PATS(Passive Anti Theft System)-BETA																											
Ford	Mustang	5.0L	~ 2014	TiVCT	SYSTEM SEARCH																										
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FDIM(Front Display Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM(Body Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	C-CM(Cruise Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DACM-C(Digital Audio Control Module C)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DDM(Driver's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSM(Driver's Seat Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GWM(Gateway Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	HUD(Head Up Display)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ICM(Information Center Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-A(Movable Roof Control Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-B(Movable Roof Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PAM(Parking Aid Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PDM(Passenger's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Mustang	5.0L	2015 ~	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	5.0L	2015 ~	TiVCT	RTM(Radio Transceiver Module)																										
Ford	Mustang	5.0L	2015 ~	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Mustang	5.0L	2015 ~	TiVCT	SCM-E(Seat Control Module E)																										
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Mustang	5.4L	4V	SYSTEM SEARCH																											
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																											
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																											
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																											
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																											
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																											
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																											
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																											
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																											
Ford	Mustang	5.4L	4V	BCM-B(Body Control Module B)																											
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																											
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																											
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																											
Ford	Mustang	5.4L	4V	FDIM(Front Display Interface Module)																											
Ford	Mustang	5.4L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Mustang	5.4L	4V	GPSM(Global Positioning System Module)																											
Ford	Mustang	5.4L	4V	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Mustang	5.4L	4V	IPC(Instrument Panel Control Module)																											
Ford	Mustang	5.4L	4V	OCSM(Occupant Classification System Module)																											
Ford	Mustang	5.4L	4V	PSCM(Power Steering Control Module)																											
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																											
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																											
Ford	Mustang	5.8L	4V	SYSTEM SEARCH																											
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																											
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																											
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																											
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																											
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																											
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																											
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																											
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																											
Ford	Mustang	5.8L	4V	BCM-B(Body Control Module B)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.8L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.8L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.8L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.8L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.8L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.8L	4V	PAM(Parking Aid Module)																										
Ford	Mustang	5.8L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM-B(Body Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ICM(Information Center Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-A(Movable Roof Control Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-B(Movable Roof Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																											
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																											
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																											
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																											
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																											
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																											
Ford	Ranger	2.5 Diesel(WL-CD)	SYSTEM SEARCH																												
Ford	Ranger	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																								V				
Ford	Ranger	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																												
Ford	Ranger	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																												
Ford	Ranger	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																												
Ford	Ranger	2.5 Diesel(WL-CD)	PATS(Passive Anti Theft System)																												
Ford	Ranger	3.0 Diesel(WE-CD)	SYSTEM SEARCH																												
Ford	Ranger	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																								V				
Ford	Ranger	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																												
Ford	Ranger	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Ranger	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Gasoline	SYSTEM SEARCH																											
Ford	Ranger	2.5 Gasoline	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Gasoline	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Gasoline	ACM(Audio Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Ranger	2.5 Gasoline	BCMii(Body Control Module)																											
Ford	Ranger	2.5 Gasoline	DDM(Driver's Door Module)																											
Ford	Ranger	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																											
Ford	Ranger	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Ranger	2.5 Gasoline	IPC(Instrument Panel Control Module)																											
Ford	Ranger	2.5 Gasoline	PAM(Parking Aid Module)																											
Ford	Ranger	2.5 Gasoline	PDM(Passenger's Door Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	SRM(Speech Recognition Module)																											
Ford	Ranger	2.5 Gasoline	TBM(Tracking And Blocking Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TRM(Trailer Module)																											
Ford	Ranger	2.5 Gasoline	PATS(Passive Anti Theft System)-BETA																											
Ford	Ranger	3.0L	Other	SYSTEM SEARCH																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	Other	IC(Instrument Cluster)																										
Ford	Ranger	3.0L	Other	OCSM(Occupant Classification System Module)																										
Ford	Ranger	3.0L	Other	4X4(4x4 Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	3.0L	FFV	SYSTEM SEARCH																										
Ford	Ranger	3.0L	FFV	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	FFV	PATS(Passive Anti Theft System)																										
Ford	Ranger	3.0L	FFV	RAP(Remote Anti-Theft/Personality Module)																										
Ford	Ranger	3.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Ranger	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																											
Ford	Ranger	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Ford	Ranger	4.0L	V6 (SOHC)	IC(Instrument Cluster)																											
Ford	Ranger	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																											
Ford	Ranger	4.0L	V6 (SOHC)	4X4(4x4 Control Module)																											
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																											
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																											
Ford	Ranger	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																											
Ford	Taurus	3.5L	4V	2008 ~ 2009	SYSTEM SEARCH																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	4X4(4x4 Control Module)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	ACM(Audio Control Module)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	APIM(Accessory Protocol Interface Module)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	DSM(Driver's Seat Module)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	IC(Instrument Cluster)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	LTM(Liftgate/Trunk Module)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	OCSM(Occupant Classification System Module)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	PAM(Parking Aid Module)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	RCM(Restraint Control Module)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	RETM(Rear Entertainment Module)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	SECM(Steering Effort Control Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	SYSTEM SEARCH																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	4X4(4x4 Control Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	APIM(Accessory Protocol Interface Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	C-CM(Cruise Control Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	DDM(Driver's Door Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSM(Driver's Seat Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	FDIM(Front Display Interface Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	GPSM(Global Positioning System Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM(Headlamp Control Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM-2(Headlamp Control Module2)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	HUD(Head Up Display)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	ILCM(Interior Lighting Control Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	IPC(Instrument Panel Control Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	PAM(Parking Aid Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	PSCM(Power Steering Control Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	RCM(Restraint Control Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	RETM(Rear Entertainment Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	RFA(Remote Function Actuator)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	SASM(Steering Angle Sensor Module)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	SYSTEM SEARCH																										
Ford	Taurus	3.5L	TiVCT	2013 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	APIM(Accessory Protocol Interface Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	BCM(Body Control Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	C-CM(Cruise Control Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	DDM(Driver's Door Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	DSM(Driver's Seat Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	DSP(Digital Signal Processing Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	FCDIM(Front Control/Display Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Taurus	3.5L	TiVCT	2013 ~	GFM(Generic Function Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	GPSM(Global Positioning System Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	HCM(Headlamp Control Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	HSWM(Heated Steering Wheel Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	HUD(Head Up Display)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	IPC(Instrument Panel Control Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	PAM(Parking Aid Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	PSCM(Power Steering Control Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	RACM(Rear Audio Control Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	RCM(Restraint Control Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	RFA(Remote Function Actuator)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	SCCM(Steering Column Control Module)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SYSTEM SEARCH																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	4X4(4x4 Control Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ACM(Audio Control Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	APIM(Accessory Protocol Interface Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	C-CM(Cruise Control Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DDM(Driver's Door Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSM(Driver's Seat Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSP(Digital Signal Processing Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FDIM(Front Display Interface Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GPSM(Global Positioning System Module)																										
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM(Headlamp Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.0L	2000 ~	SYSTEM SEARCH																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	2000 ~	EATC(Electronic Automatic Temperature Control)																										
Ford	Taurus	3.0L	2000 ~	GEM(Generic Electronic Module)																										
Ford	Taurus	3.0L	2000 ~	IC(Instrument Cluster)																										
Ford	Taurus	3.0L	2000 ~	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	SYSTEM SEARCH																										
Ford	Taurus	3.0L	~ 1999	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	~ 1999	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	~ 1999	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	RIM(Remote Immobilizer Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																											
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SYSTEM SEARCH																											
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PCM(PowerTrain Control Module)													V												V		
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ABS(Anti-Lock Brake System)																											
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ACM(Audio Control Module)																											
Ford	Transit	1.8L DIESEL	2007 ~ 2009	GEM(Generic Electronic Module)																											
Ford	Transit	1.8L DIESEL	2007 ~ 2009	IC(Instrument Cluster)																											
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PAM(Parking Aid Module)																											
Ford	Transit	1.8L DIESEL	2007 ~ 2009	RCM(Restraint Control Module)																											
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SRM(Speech Recognition Module)																											
Ford	Transit	2.0L	2001 ~ 2004	SYSTEM SEARCH																											
Ford	Transit	2.0L	2001 ~ 2004	PCM(PowerTrain Control Module)																											
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																											
Ford	Transit	2.0L	2001 ~ 2004	ASM(Auto Shift Manual)																											
Ford	Transit	2.0L	2001 ~ 2004	ABS(Anti-Lock Brake System)																											
Ford	Transit	2.0L	2001 ~ 2004	HEC(Hybrid Electrical Cluster)																											
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																											
Ford	Transit	2.3L DIESEL	2004 ~ 2006	SYSTEM SEARCH																											
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																									V	V

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																											
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																											
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																											
Ford	Transit	2.3L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																											
Ford	Transit	2.3L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																											
Ford	Transit	2.3L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																											
Ford	Transit	2.3L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																											
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	SYSTEM SEARCH																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																									V	V
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	CSM(Central Security Module)																											
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																											
Ford	Transit	2.4L DIESEL	2006.5	SYSTEM SEARCH																											
Ford	Transit	2.4L DIESEL	2006.5	PCM(PowerTrain Control Module)																									V	V
Ford	Transit	2.4L DIESEL	2006.5	ABS(Anti-Lock Brake System)																											
Ford	Transit	2.4L DIESEL	2006.5	ACM(Audio Control Module)																											
Ford	Transit	2.4L DIESEL	2006.5	BCMii(Body Control Module)																											
Ford	Transit	2.4L DIESEL	2006.5	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Transit	2.4L DIESEL	2006.5	IPC(Instrument Panel Control Module)																											
Ford	Transit	2.4L DIESEL	2006.5	PAM(Parking Aid Module)																											
Ford	Transit	2.4L DIESEL	2006.5	RCM(Restraint Control Module)																											
Ford	Transit	2.4L DIESEL	2006.5	TBM(Tracking And Blocking Module)																											
Ford	Transit	2.5L DIESEL	SYSTEM SEARCH																												
Ford	Transit	2.5L DIESEL	PCM(PowerTrain Control Module)																												
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																												
Ford	Transit	2.5L DIESEL	ASM(Auto Shift Manual)																												
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																											
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Transit	2.5L DIESEL	RCM(Restraint Control Module)																												
Ford	Transit	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																												
Ford	Transit	2.5L DIESEL	CSM(Central Security Module)																												
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																												
Ford	Transit	2.5L DIESEL	RIM(Remote Immobilizer Module)																												
Ford	Transit	2.5L DIESEL	ACM(Audio Control Module)																												
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																									V	V
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Control Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																											
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																											
Ford	Transit	3.7L	TiVCT	SYSTEM SEARCH																											
Ford	Transit	3.7L	TiVCT	PCM(PowerTrain Control Module)																											
Ford	Transit	3.7L	TiVCT	ABS(Anti-Lock Brake System)																											
Ford	Transit	3.7L	TiVCT	ACM(Audio Control Module)																											
Ford	Transit	3.7L	TiVCT	APIM(Accessory Protocol Control Module)																											
Ford	Transit	3.7L	TiVCT	BCM(Body Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Ford	Transit	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																											
Ford	Transit	3.7L	TiVCT	FCIM(Front Controls Interface Module)																											
Ford	Transit	3.7L	TiVCT	GPSM(Global Positioning System Module)																											
Ford	Transit	3.7L	TiVCT	IPC(Instrument Panel Control Module)																											
Ford	Transit	3.7L	TiVCT	IPM-A(Image Processing Module A)																											
Ford	Transit	3.7L	TiVCT	IPM-B(Image Processing Module B)																											
Ford	Transit	3.7L	TiVCT	PAM(Park Aid Module)																											
Ford	Transit	3.7L	TiVCT	RCM(Restraint Control Module)																											
Ford	Transit	3.7L	TiVCT	SASM(Steering Angle Sensor Module)																											
Ford	Transit	3.7L	TiVCT	TBC(Trailer Brake Control Module)																											
Ford	Transit	3.7L	TiVCT	TRM(Trailer Module)																											
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																											
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)													V												V	
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																											
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																											
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																											
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																											
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																											
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																											
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																											
Ford	Thunderbird	3.9L	4V	SYSTEM SEARCH																											
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																											
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																											
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																											
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																											
Ford	Thunderbird	3.9L	4V	ACM(Audio Control Module)																											
Ford	Thunderbird	3.9L	4V	DDM(Driver's Door Module)																											
Ford	Thunderbird	3.9L	4V	EATC(Electronic Automatic Temperature Control)																											
Ford	Thunderbird	3.9L	4V	GEM(Generic Electronic Module)																											
Ford	Thunderbird	3.9L	4V	HEC(Hybrid Electrical Cluster)																											
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																											
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																											
Ford	Thunderbird	3.9L	4V	REM(Rear Electronic Module)																											
Lincoln	Aviator	4.6L	4V	SYSTEM SEARCH																											
Lincoln	Aviator	4.6L	4V	PCM(Powertrain Control Module)																											
Lincoln	Aviator	4.6L	4V	ABS(Anti-Lock Brake System)																											
Lincoln	Aviator	4.6L	4V	DCSM(Driver-Dual Climate Control Seat Module)																											
Lincoln	Aviator	4.6L	4V	DSM(Driver's Seat Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	Aviator	4.6L	4V	EATC(Electronic Automatic Temperature Control)																											
Lincoln	Aviator	4.6L	4V	IC(Instrument Cluster)																											
Lincoln	Aviator	4.6L	4V	PAM(Parking Aid Module)																											
Lincoln	Aviator	4.6L	4V	RCM(Restraint Control Module)																											
Lincoln	Aviator	4.6L	4V	TPM(Tire Pressure Monitor)																											
Lincoln	Aviator	4.6L	4V	VAPS(Variable Assist Power Steering)																											
Lincoln	Aviator	4.6L	4V	VSM(Vehicle Security Module)																											
Lincoln	Continental	4.6L	4V	SYSTEM SEARCH																											
Lincoln	Continental	4.6L	4V	PCM(PowerTrain Control Module)																											
Lincoln	Continental	4.6L	4V	ABS(Anti-Lock Brake System)																											
Lincoln	Continental	4.6L	4V	ACM(Audio Control Module)																											
Lincoln	Continental	4.6L	4V	CPM(Cellular Phone Module)																											
Lincoln	Continental	4.6L	4V	DDM(Driver's Door Module)																											
Lincoln	Continental	4.6L	4V	DSM(Driver's Seat Module)																											
Lincoln	Continental	4.6L	4V	LCM(Lighting Control Module)																											
Lincoln	Continental	4.6L	4V	NGSC(Next Generation Speed Control Module)																											
Lincoln	Continental	4.6L	4V	RCM(Restraint Control Module)																											
Lincoln	Continental	4.6L	4V	VDM(Vehicle Dynamic Module)																											
Lincoln	Continental	4.6L	4V	VIC(Virtual Image Cluster)																											
Lincoln	Continental	4.6L	4V	EATC(Electronic Automatic Temperature Control)																											
Lincoln	Continental	4.6L	4V	PATS(Passive Anti Theft System)																											
Lincoln	LS	ALL	SYSTEM SEARCH																												
Lincoln	LS	ALL	PCM(Powertrain Control Module)																												
Lincoln	LS	ALL	PCM(Powertrain Control Module)																												
Lincoln	LS	ALL	ABS(Anti-Lock Brake System)																												
Lincoln	LS	ALL	DCSM(Driver-Dual Climate Control Seat Module)																												
Lincoln	LS	ALL	DDM(Driver's Door Module)																												
Lincoln	LS	ALL	DSM(Driver's Seat Module)																												
Lincoln	LS	ALL	EPB(Electronic Parking Brake)																												
Lincoln	LS	ALL	PAM(Parking Aid Module)																												
Lincoln	LS	ALL	RCM(Restraint Control Module)																												
Lincoln	LS	ALL	REM(Rear Electronic Module)																												
Lincoln	LS	ALL	REM(Rear Electronic Module)																												
Lincoln	LS	ALL	SCLM(Steering Column Locking Module)																												
Lincoln	LS	ALL	EATC(Electronic Automatic Temperature Control)																												
Lincoln	LS	ALL	GEM(Generic Electronic Module)																												
Lincoln	LS	ALL	HEC(Hybrid Electrical Cluster)																												
Lincoln	LS	ALL	PCSM(Passenger Climate Control Seat Module)																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	MKS	3.7L	4V	2009	SYSTEM SEARCH																										
Lincoln	MKS	3.7L	4V	2009	PCM(Powertrain Control Module)																										
Lincoln	MKS	3.7L	4V	2009	4X4(4x4 Control Module)																										
Lincoln	MKS	3.7L	4V	2009	ABS(Anti-Lock Brake System)																										
Lincoln	MKS	3.7L	4V	2009	ACM(Audio Control Module)																										
Lincoln	MKS	3.7L	4V	2009	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKS	3.7L	4V	2009	C-CM(Cruise Control Module)																										
Lincoln	MKS	3.7L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKS	3.7L	4V	2009	DDM(Driver's Door Module)																										
Lincoln	MKS	3.7L	4V	2009	DSM(Driver's Seat Module)																										
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																										
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																										
Lincoln	MKS	3.7L	4V	2009	FCIM(Front Controls Interface Module)																										
Lincoln	MKS	3.7L	4V	2009	FDIM(Front Display Interface Module)																										
Lincoln	MKS	3.7L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKS	3.7L	4V	2009	HCM(Headlamp Control Module)																										
Lincoln	MKS	3.7L	4V	2009	HCM-2(Headlamp Control Module2)																										
Lincoln	MKS	3.7L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKS	3.7L	4V	2009	IPC(Instrument Panel Control Module)																										
Lincoln	MKS	3.7L	4V	2009	OCSM(Occupant Classification System Module)																										
Lincoln	MKS	3.7L	4V	2009	PAM(Parking Aid Module)																										
Lincoln	MKS	3.7L	4V	2009	RCM(Restraint Control Module)																										
Lincoln	MKS	3.7L	4V	2009	RFA(Remote Function Actuator)																										
Lincoln	MKS	3.7L	4V	2010 ~	SYSTEM SEARCH																										
Lincoln	MKS	3.7L	4V	2010 ~	PCM(PowerTrain Control Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	4X4(4x4 Control Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	ABS(Anti-Lock Brake System)																										
Lincoln	MKS	3.7L	4V	2010 ~	ACM(Audio Control Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	C-CM(Cruise Control Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	DDM(Driver's Door Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	DSM(Driver's Seat Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	FCIM(Front Controls Interface Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	FDIM(Front Display Interface Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	MKS	3.7L	4V	2010 ~	GPSM(Global Positioning System Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	HCM(Headlamp Control Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	HCM-2(Headlamp Control Module2)																										
Lincoln	MKS	3.7L	4V	2010 ~	HUD(Head Up Display)																										
Lincoln	MKS	3.7L	4V	2010 ~	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKS	3.7L	4V	2010 ~	ILCM(Interior Lighting Control Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	IPC(Instrument Panel Control Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	OCSM(Occupant Classification System Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	PAM(Parking Aid Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	PSCM(Power Steering Control Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	RCM(Restraint Control Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	RFA(Remote Function Actuator)																										
Lincoln	MKS	3.7L	4V	2010 ~	SASM(Steering Angle Sensor Module)																										
Lincoln	MKS	3.7L	4V	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKS	3.7L	4V	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SYSTEM SEARCH																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS(Anti-Lock Brake System)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	4X4(4x4 Control Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM(Audio Control Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	C-CM(Cruise Control Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM(Driver's Door Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM(Driver's Seat Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FDIM(Front Display Interface Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GPSM(Global Positioning System Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM(Headlamp Control Module)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM-2(Headlamp Control Module2)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HUD(Head Up Display)																										
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC(Heating Ventilation Air Conditioning)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKX	3.5L	4V	2007	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2007	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2007	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2007	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2007	EATC(Electronic Automatic Temperature Control)																									
Lincoln	MKX	3.5L	4V	2007	GEM(Generic Electronic Module)																									
Lincoln	MKX	3.5L	4V	2007	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2007	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2007	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2007	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2007	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2007	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2007	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2007	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2007	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2008	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2008	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2008	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2008	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2008	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2008	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	MKX	3.5L	4V	2008	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2008	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2008	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2008	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2008	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2008	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2008	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2008	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2008	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2009	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2009	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2009	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2009	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2009	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2010	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2010	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2010	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	MKX	3.5L	4V	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2010	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2010	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2010	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2010	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2010	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2010	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2010	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKZ	3.0L	2006	SYSTEM SEARCH																										
Lincoln	MKZ	3.0L	2006	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.0L	2006	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.0L	2006	ACM(Audio Control Module)																										
Lincoln	MKZ	3.0L	2006	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.0L	2006	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.0L	2006	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.0L	2006	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.0L	2006	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.0L	2006	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.0L	2006	IC(Instrument Cluster)																										
Lincoln	MKZ	3.0L	2006	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.0L	2006	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.0L	2006	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2007	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2007	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2007	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2007	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2007	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2007	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2007	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	MKZ	3.5L	2007	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2007	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.5L	2007	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.5L	2007	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2007	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2007	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2007	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2007	PATS(Passive Anti Theft System)																										
Lincoln	MKZ	3.5L	2008	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2008	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2008	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2008	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2008	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2008	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2008	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2008	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2008	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2008	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2008	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2008	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2008	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2008	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2008	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2008	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2009	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2009	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2009	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2009	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2009	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2009	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2009	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2009	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2009	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	MKZ	3.5L	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Lincoln	MKZ	3.5L	2009	HVAC(Heating Ventilation Air Conditioning)																											
Lincoln	MKZ	3.5L	2009	IC(Instrument Cluster)																											
Lincoln	MKZ	3.5L	2009	OCSM(Occupant Classification System Module)																											
Lincoln	MKZ	3.5L	2009	PAM(Parking Aid Module)																											
Lincoln	MKZ	3.5L	2009	RCM(Restraint Control Module)																											
Lincoln	MKZ	3.5L	2009	SDARS(Satellite Digital Audio Receiver System)																											
Lincoln	MKZ	3.5L	2009	TCM(Transmission Control Module)																											
Lincoln	MKZ	3.5L	2010	SYSTEM SEARCH																											
Lincoln	MKZ	3.5L	2010	PCM(PowerTrain Control Module)																											
Lincoln	MKZ	3.5L	2010	4X4(4x4 Control Module)																											
Lincoln	MKZ	3.5L	2010	ABS(Anti-Lock Brake System)																											
Lincoln	MKZ	3.5L	2010	ACM(Audio Control Module)																											
Lincoln	MKZ	3.5L	2010	APIM(Accessory Protocol Interface Module)																											
Lincoln	MKZ	3.5L	2010	DCSM(Driver-Dual Climate Control Seat Module)																											
Lincoln	MKZ	3.5L	2010	DDM(Driver's Door Module)																											
Lincoln	MKZ	3.5L	2010	DSM(Driver's Seat Module)																											
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																											
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																											
Lincoln	MKZ	3.5L	2010	FCIM(Front Controls Interface Module)																											
Lincoln	MKZ	3.5L	2010	FDIM(Front Display Interface Module)																											
Lincoln	MKZ	3.5L	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Lincoln	MKZ	3.5L	2010	GPSM(Global Positioning System Module)																											
Lincoln	MKZ	3.5L	2010	HCM(Headlamp Control Module)																											
Lincoln	MKZ	3.5L	2010	HVAC(Heating Ventilation Air Conditioning)																											
Lincoln	MKZ	3.5L	2010	ILCM(Interior Lighting Control Module)																											
Lincoln	MKZ	3.5L	2010	IPC(Instrument Panel Control Module)																											
Lincoln	MKZ	3.5L	2010	OCSM(Occupant Classification System Module)																											
Lincoln	MKZ	3.5L	2010	PAM(Parking Aid Module)																											
Lincoln	MKZ	3.5L	2010	RCM(Restraint Control Module)																											
Lincoln	MKZ	3.5L	2010	SOD-L(Side Obstacle Detection Control Module Left)																											
Lincoln	MKZ	3.5L	2010	SOD-R(Side Obstacle Detection Control Module Right)																											
Lincoln	MKZ	3.5L	2010	TCM(Transmission Control Module)																											
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																											
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																											
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																											
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACCM(Air Conditioning Control Module)																											
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffiure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRCM(Transmission Range Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM(Body Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM(Transmission Range Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Lincoln	Navigator	2007 ~	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	APIM(Accessory Protocol Interface Module)																										
Lincoln	Navigator	2007 ~	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GPSM(Global Positioning System Module)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	2007 ~	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	2007 ~	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	2007 ~	5.4L	PRB(Power Running Board)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCU(Audio Rear Control Unit)																										
Lincoln	Navigator	2007 ~	5.4L	RETM(Rear Entertainment Module)																										
Lincoln	Navigator	2007 ~	5.4L	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	Navigator	2007 ~	5.4L	TCCM(Transfer Case Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	TCM(Transmission Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	2007 ~	5.4L	4X4(4x4 Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PATS(Passive Anti Theft System)																										
Lincoln	Navigator	~ 2007	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																											
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																											
Lincoln	Navigator	~ 2007	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																											
Lincoln	Navigator	~ 2007	5.4L	DSM(Driver's Seat Module)																											
Lincoln	Navigator	~ 2007	5.4L	GEM(Generic Electronic Module)																											
Lincoln	Navigator	~ 2007	5.4L	EATC(Electronic Automatic Temperature Control)																											
Lincoln	Navigator	~ 2007	5.4L	IC(Instrument Cluster)																											
Lincoln	Navigator	~ 2007	5.4L	LTM(Liftgate/Trunk Module)																											
Lincoln	Navigator	~ 2007	5.4L	PAM(Parking Aid Module)																											
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																											
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																											
Lincoln	Navigator	~ 2007	5.4L	VDM(Vehicle Dynamic Module)																											
Lincoln	Navigator	~ 2007	5.4L	RIM(Remote Immobilizer Module)																											
Lincoln	Navigator	~ 2007	5.4L	VSM(Vehicle Security Module)																											
Lincoln	Town Car	4.6L	2V	SYSTEM SEARCH																											
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																											
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																											
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																											
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																											
Lincoln	Town Car	4.6L	2V	EATC(Electronic Automatic Temperature Control)																											
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																											
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																											
Lincoln	Town Car	4.6L	2V	LCM(Lighting Control Module)																											
Lincoln	Town Car	4.6L	2V	VDM(Vehicle Dynamic Module)																											
Lincoln	Town Car	4.6L	2V	DDM(Driver's Door Module)																											
Lincoln	Town Car	4.6L	2V	DSM(Driver's Seat Module)																											
Lincoln	Town Car	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																											
Lincoln	Town Car	4.6L	2V	RATC(Rear Air Temperature Control)																											
Lincoln	Town Car	4.6L	2V	LTM(Liftgate/Trunk Module)																											
Lincoln	Town Car	4.6L	2V	PAM(Parking Aid Module)																											
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																											
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																											
Lincoln	Town Car	4.6L	2V	HEC(Hybrid Electrical Cluster)																											
Lincoln	Town Car	4.6L	2V	NGSC(Next Generation Speed Control Module)																											
Lincoln	Town Car	4.6L	2V	RASM(Rear Air Suspension Module)																											
Mercury	Grand Marquis	4.6L	2V	SYSTEM SEARCH																											
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																											
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																											
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																											
Mercury	Grand Marquis	4.6L	2V	DDM(Driver's Door Module)																											
Mercury	Grand Marquis	4.6L	2V	IC(Instrument Cluster)																											
Mercury	Grand Marquis	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																											
Mercury	Grand Marquis	4.6L	2V	LCM(Lighting Control Module)																											
Mercury	Grand Marquis	4.6L	2V	MC(Message Center)																											
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																											
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																											
Mercury	Grand Marquis	4.6L	2V	RIM(Remote Immobilizer Module)																											
Mercury	Grand Marquis	4.6L	2V	GEM(Generic Electronic Module)																											
Mercury	Grand Marquis	4.6L	2V	VDM(Vehicle Dynamic Module)																											
Mercury	Marauder	4.6L	4V	SYSTEM SEARCH																											
Mercury	Marauder	4.6L	4V	PCM(Powertrain Control Module)																											
Mercury	Marauder	4.6L	4V	ABS(Anti-Lock Brake System)																											
Mercury	Marauder	4.6L	4V	EATC(Electronic Automatic Temperature Control)																											
Mercury	Marauder	4.6L	4V	RASM(Rear Air Suspension Module)																											
Mercury	Marauder	4.6L	4V	VAPS(Variable Assist Power Steering)																											
Mercury	Marauder	4.6L	4V	DDM(Driver's Door Module)																											
Mercury	Marauder	4.6L	4V	LCM(Lighting Control Module)																											
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																											
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																											
Mercury	Milan	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	Milan	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																											
Mercury	Milan	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																											
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																											
Mercury	Milan	3.0L	4V	SYSTEM SEARCH																											
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																											
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																											
Mercury	Milan	3.0L	4V	4X4(4x4 Control Module)																											
Mercury	Milan	3.0L	4V	ABS(Anti-Lock Brake System)																											
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																											
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	Milan	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Milan	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	Milan	3.0L	4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Milan	3.0L	4V	PATS(Passive Anti Theft System)																										
Mercury	Montego	3.0L	4V	SYSTEM SEARCH																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Montego	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Montego	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Montego	3.0L	4V	DSM(Driver's Seat Module)																										
Mercury	Montego	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Montego	3.0L	4V	GEM(Generic Electronic Module)																										
Mercury	Montego	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Montego	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Montego	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Montego	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Mercury	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Mercury	Mountaineer	2010 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2010 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2010 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2010 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2010 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2010 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.6L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	Mountaineer	2009 MY	4.6L	TCM(Transmission Control Module)																											
Mercury	Mountaineer	2009 MY	4.6L	4X4(4x4 Control Module)																											
Mercury	Mountaineer	2009 MY	4.6L	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																											
Mercury	Mountaineer	2009 MY	4.6L	GPSM(Global Positioning System Module)																											
Mercury	Mountaineer	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																											
Mercury	Mountaineer	2009 MY	4.6L	DSM(Driver's Seat Module)																											
Mercury	Mountaineer	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Mercury	Mountaineer	2009 MY	4.6L	IC(Instrument Cluster)																											
Mercury	Mountaineer	2009 MY	4.6L	OCSM(Occupant Classification System Module)																											
Mercury	Mountaineer	2009 MY	4.6L	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2009 MY	4.6L	PRB(Power Running Board)																											
Mercury	Mountaineer	2009 MY	4.6L	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2009 MY	4.6L	RETM(Rear Entertainment Module)																											
Mercury	Mountaineer	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																											
Mercury	Mountaineer	2009 MY	4.0L	SYSTEM SEARCH																											
Mercury	Mountaineer	2009 MY	4.0L	PCM(Powertrain Control Module)																											
Mercury	Mountaineer	2009 MY	4.0L	4X4(4x4 Control Module)																											
Mercury	Mountaineer	2009 MY	4.0L	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2009 MY	4.0L	DSM(Driver's Seat Module)																											
Mercury	Mountaineer	2009 MY	4.0L	EATC(Electronic Automatic Temperature Control)																											
Mercury	Mountaineer	2009 MY	4.0L	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2009 MY	4.0L	IC(Instrument Cluster)																											
Mercury	Mountaineer	2009 MY	4.0L	OCSM(Occupant Classification System Module)																											
Mercury	Mountaineer	2009 MY	4.0L	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2009 MY	4.0L	PRB(Power Running Board)																											
Mercury	Mountaineer	2009 MY	4.0L	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2009 MY	4.0L	RETM(Rear Entertainment Module)																											
Mercury	Mountaineer	2009 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																											
Mercury	Mountaineer	2008 MY	4.6L	SYSTEM SEARCH																											
Mercury	Mountaineer	2008 MY	4.6L	PCM(Powertrain Control Module)																											
Mercury	Mountaineer	2008 MY	4.6L	TCM(Transmission Control Module)																											
Mercury	Mountaineer	2008 MY	4.6L	4X4(4x4 Control Module)																											
Mercury	Mountaineer	2008 MY	4.6L	ABS(Anti-Lock Brake System)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2008 MY	4.6L	APIM(Accessory Protocol Interface Module)																											
Mercury	Mountaineer	2008 MY	4.6L	GPSM(Global Positioning System Module)																											
Mercury	Mountaineer	2008 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																											
Mercury	Mountaineer	2008 MY	4.6L	DSM(Driver's Seat Module)																											
Mercury	Mountaineer	2008 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Mercury	Mountaineer	2008 MY	4.6L	IC(Instrument Cluster)																											
Mercury	Mountaineer	2008 MY	4.6L	OCSM(Occupant Classification System Module)																											
Mercury	Mountaineer	2008 MY	4.6L	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2008 MY	4.6L	PRB(Power Running Board)																											
Mercury	Mountaineer	2008 MY	4.6L	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2008 MY	4.6L	RETM(Rear Entertainment Module)																											
Mercury	Mountaineer	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																											
Mercury	Mountaineer	2008 MY	4.0L	SYSTEM SEARCH																											
Mercury	Mountaineer	2008 MY	4.0L	PCM(Powertrain Control Module)																											
Mercury	Mountaineer	2008 MY	4.0L	4X4(4x4 Control Module)																											
Mercury	Mountaineer	2008 MY	4.0L	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2008 MY	4.0L	DSM(Driver's Seat Module)																											
Mercury	Mountaineer	2008 MY	4.0L	EATC(Electronic Automatic Temperature Control)																											
Mercury	Mountaineer	2008 MY	4.0L	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2008 MY	4.0L	IC(Instrument Cluster)																											
Mercury	Mountaineer	2008 MY	4.0L	OCSM(Occupant Classification System Module)																											
Mercury	Mountaineer	2008 MY	4.0L	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2008 MY	4.0L	PRB(Power Running Board)																											
Mercury	Mountaineer	2008 MY	4.0L	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2008 MY	4.0L	RETM(Rear Entertainment Module)																											
Mercury	Mountaineer	2008 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																											
Mercury	Mountaineer	2007 MY	4.6L	SYSTEM SEARCH																											
Mercury	Mountaineer	2007 MY	4.6L	PCM(Powertrain Control Module)																											
Mercury	Mountaineer	2007 MY	4.6L	TCM(Transmission Control Module)																											
Mercury	Mountaineer	2007 MY	4.6L	4X4(4x4 Control Module)																											
Mercury	Mountaineer	2007 MY	4.6L	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2007 MY	4.6L	APIM(Accessory Protocol Interface Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	Mountaineer	2007 MY	4.6L	GPSM(Global Positioning System Module)																											
Mercury	Mountaineer	2007 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																											
Mercury	Mountaineer	2007 MY	4.6L	DSM(Driver's Seat Module)																											
Mercury	Mountaineer	2007 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Mercury	Mountaineer	2007 MY	4.6L	IC(Instrument Cluster)																											
Mercury	Mountaineer	2007 MY	4.6L	OCSM(Occupant Classification System Module)																											
Mercury	Mountaineer	2007 MY	4.6L	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2007 MY	4.6L	PRB(Power Running Board)																											
Mercury	Mountaineer	2007 MY	4.6L	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2007 MY	4.6L	RETM(Rear Entertainment Module)																											
Mercury	Mountaineer	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																											
Mercury	Mountaineer	2007 MY	4.0L	SYSTEM SEARCH																											
Mercury	Mountaineer	2007 MY	4.0L	PCM(Powertrain Control Module)																											
Mercury	Mountaineer	2007 MY	4.0L	4X4(4x4 Control Module)																											
Mercury	Mountaineer	2007 MY	4.0L	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2007 MY	4.0L	DSM(Driver's Seat Module)																											
Mercury	Mountaineer	2007 MY	4.0L	EATC(Electronic Automatic Temperature Control)																											
Mercury	Mountaineer	2007 MY	4.0L	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2007 MY	4.0L	IC(Instrument Cluster)																											
Mercury	Mountaineer	2007 MY	4.0L	OCSM(Occupant Classification System Module)																											
Mercury	Mountaineer	2007 MY	4.0L	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2007 MY	4.0L	PRB(Power Running Board)																											
Mercury	Mountaineer	2007 MY	4.0L	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2007 MY	4.0L	RETM(Rear Entertainment Module)																											
Mercury	Mountaineer	2007 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																											
Mercury	Mountaineer	2006 MY	4.6L	SYSTEM SEARCH																											
Mercury	Mountaineer	2006 MY	4.6L	PCM(Powertrain Control Module)																											
Mercury	Mountaineer	2006 MY	4.6L	TCM(Transmission Control Module)																											
Mercury	Mountaineer	2006 MY	4.6L	4X4(4x4 Control Module)																											
Mercury	Mountaineer	2006 MY	4.6L	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																											
Mercury	Mountaineer	2006 MY	4.6L	APIM(Accessory Protocol Interface Module)																											
Mercury	Mountaineer	2006 MY	4.6L	GPSM(Global Positioning System Module)																											
Mercury	Mountaineer	2006 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																											
Mercury	Mountaineer	2006 MY	4.6L	DSM(Driver's Seat Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral accleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	Mountaineer	2006 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2006 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2006 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2006 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2006 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2003 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2003 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2003 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2003 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2003 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2003 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2003 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2002 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2002 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2002 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2002 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	Mountaineer	2002 MY	GEM(Generic Electronic Module)																												
Mercury	Mountaineer	2002 MY	PAM(Parking Aid Module)																												
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																												
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																												
Mercury	Mountaineer	2001 MY	SYSTEM SEARCH																												
Mercury	Mountaineer	2001 MY	PCM(PowerTrain Control Module)																												
Mercury	Mountaineer	2001 MY	ABS(Anti-Lock Brake System)																												
Mercury	Mountaineer	2001 MY	RCM(Restraint Control Module)																												
Mercury	Mountaineer	2001 MY	RIM(Remote Immobilizer Module)																												
Mercury	Mountaineer	2001 MY	GEM(Generic Electronic Module)																												
Mercury	Mountaineer	2001 MY	PAM(Parking Aid Module)																												
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																												
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																												
Mercury	Mountaineer	2000 MY	SYSTEM SEARCH																												
Mercury	Mountaineer	2000 MY	PCM(PowerTrain Control Module)																												
Mercury	Mountaineer	2000 MY	ABS(Anti-Lock Brake System)																												
Mercury	Mountaineer	2000 MY	RCM(Restraint Control Module)																												
Mercury	Mountaineer	2000 MY	RIM(Remote Immobilizer Module)																												
Mercury	Mountaineer	2000 MY	GEM(Generic Electronic Module)																												
Mercury	Mountaineer	2000 MY	PAM(Parking Aid Module)																												
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																												
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																												
Mercury	Mountaineer	1999 MY	SYSTEM SEARCH																												
Mercury	Mountaineer	1999 MY	PCM(PowerTrain Control Module)																												
Mercury	Mountaineer	1999 MY	ABS(Anti-Lock Brake System)																												
Mercury	Mountaineer	1999 MY	RCM(Restraint Control Module)																												
Mercury	Mountaineer	1999 MY	RIM(Remote Immobilizer Module)																												
Mercury	Mountaineer	1999 MY	PAM(Parking Aid Module)																												
Mercury	Mountaineer	1998 MY	SYSTEM SEARCH																												
Mercury	Mountaineer	1998 MY	PCM(PowerTrain Control Module)																												
Mercury	Mountaineer	1998 MY	ABS(Anti-Lock Brake System)																												
Mercury	Mountaineer	1998 MY	RCM(Restraint Control Module)																												
Mercury	Mountaineer	1998 MY	RIM(Remote Immobilizer Module)																												
Mercury	Mountaineer	1997 MY	SYSTEM SEARCH																												
Mercury	Mountaineer	1997 MY	PCM(PowerTrain Control Module)																												
Mercury	Mountaineer	1997 MY	ABS(Anti-Lock Brake System)																												
Mercury	Mountaineer	1997 MY	RCM(Restraint Control Module)																												
Mercury	Mountaineer	1997 MY	RIM(Remote Immobilizer Module)																												

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	ESP Conffure the pressure sensor	ESP Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	ESP Calibrate longitudinal Acceleration Sensor	ESP Inhibit longitudical Accelerometer Monitoring	Module Reset	Configure the lateral acceleration sensor	ABS Module Initialization	Steering Ahead Adaption Angle Reset	Pull Drift Compensation Enable/Disable	Clear Self learning Data	Injector Correction Factors	Reset the EGR Valve Learned Values	Reset Change Air Cooler Bypass Valve Position Offset	Reset the Cooling Fan Motor Learned Values	Reset the Diesel Pariculate Filter Learned Values	Diesel Particulate Filter Static Regeneration	New FACM(Fuel Additive Control Module)	Refill the FAT(Fuel Additive Tank)	Configure pressure sensor	Configure Yaw rate and Lateral acceleration sensors	Configure longitudinal acceleration sensor	Passenger System Reset/OCS Reset	Fuel Injector Correction Factors	Reset the DPF learned values	Reset the DPF differential pressure sensor learned value
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																											
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Vehicle Info.	Vehicle Info.	Vehicle Info.																												
Ford	Crown Victoria	4.6L	2V	SYSTEM SEARCH																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	DDM(Driver's Door Module)																										
Ford	Crown Victoria	4.6L	2V	IC(Instrument Cluster)																										
Ford	Crown Victoria	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Crown Victoria	4.6L	2V	LCM(Lighting Control Module)																										
Ford	Crown Victoria	4.6L	2V	MC(Message Center)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	Crown Victoria	4.6L	2V	GEM(Generic Electronic Module)																										
Ford	Crown Victoria	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.4L	DIESEL	SYSTEM SEARCH																										
Ford	Ecosport	1.4L	DIESEL	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.4L	DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.4L	DIESEL	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.4L	DIESEL	IC(Instrument Cluster)																										
Ford	Ecosport	1.4L	DIESEL	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	FFV	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Ecosport	1.6L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	FFV	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Escort	2.0L	SYSTEM SEARCH																											
Ford	Escort	2.0L	PCM(PowerTrain Control Module)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ECS(Electronic Crash Sensor)																											
Ford	Escort	2.0L	PATS(Passive Anti Theft System)																											
Ford	Escort	2.0L	RAP(Remote Anti-Theft/Personality Module)																											
Ford	Edge	3.5L	4V	SYSTEM SEARCH																										
Ford	Edge	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Edge	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Edge	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Edge	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	4V	IC(Instrument Cluster)																										
Ford	Edge	3.5L	4V	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Edge	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Edge	3.5L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Edge	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.5L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.5L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	TiVCT	RFA(Remote Function Actuator)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Edge	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.5L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.5L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Edge	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.7L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.7L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.7L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.7L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.7L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.7L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Edge	3.7L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.7L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.7L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.7L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.7L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.7L	TiVCT	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.7L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Escape	Up to 2004	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Escape	Up to 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	Up to 2004	Immobilizer																											
Ford	Escape	Up to 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	Up to 2004	RCM(Restraint Control Module)																											
Ford	Escape	Up to 2004	GEM(Generic Electronic Module)																											
Ford	Escape	From 2004	SYSTEM SEARCH																											
Ford	Escape	From 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	From 2004	PATS(Passive Anti Theft System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	RCM(Restraint Control Module)																											
Ford	Escape	From 2004	IC(Instrument cluster)																											
Ford	Escape	From 2004	GEM(Generic Electronic Module)																											
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Excursion	GASOLINE	SYSTEM SEARCH																											
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											
Ford	Excursion	GASOLINE	ABS(Anti-Lock Brake System)																											
Ford	Excursion	GASOLINE	CSM(Central Security Module)																											
Ford	Excursion	GASOLINE	DSM(Driver's Seat Module)																											
Ford	Excursion	GASOLINE	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	GASOLINE	ECS(Electronic Crash Sensor)																											
Ford	Excursion	GASOLINE	GEM(Generic Electronic Module)																											
Ford	Excursion	GASOLINE	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	GASOLINE	OTC(Overhead Trip Computer)																											
Ford	Excursion	GASOLINE	PAM(Parking Aid Module)																											
Ford	Excursion	GASOLINE	PATS(Passive Anti Theft System)																											
Ford	Excursion	GASOLINE	TCM(Transmission Control Module)																											
Ford	Excursion	GASOLINE	VSM(Vehicle Security Module)																											
Ford	Excursion	DIESEL	SYSTEM SEARCH																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Excursion	DIESEL	CSM(Central Security Module)																											
Ford	Excursion	DIESEL	DSM(Driver's Seat Module)																											
Ford	Excursion	DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	DIESEL	ECS(Electronic Crash Sensor)																											
Ford	Excursion	DIESEL	GEM(Generic Electronic Module)																											
Ford	Excursion	DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	DIESEL	OTC(Overhead Trip Computer)																											
Ford	Excursion	DIESEL	PAM(Parking Aid Module)																											
Ford	Excursion	DIESEL	PATS(Passive Anti Theft System)																											
Ford	Excursion	DIESEL	TCM(Transmission Control Module)																											
Ford	Excursion	DIESEL	VSM(Vehicle Security Module)																											
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	EATC(Electronic Automatic Temperature Control)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VSM(Vehicle Security Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TBC(Trailer Brake Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCCM(Transfer Case Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	GEM(Generic Electronic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	5.4L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VSM(Vehicle Security Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	APIM(Accessory Protocol Interface Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GPSM(Global Positioning System Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	4.6L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PRB(Power Running Board)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCU(Audio Rear Control Unit)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RETM(Rear Entertainment Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	TCM(Transmission Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	4X4(4x4 Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VSM(Vehicle Security Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2015 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2014 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PATS(Passive Anti Theft System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2012 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2010 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2009 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2005 MY	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2005 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2005 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2005 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2005 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2005 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2004 MY	SYSTEM SEARCH																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2004 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2004 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2004 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2004 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2004 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2003 MY	SYSTEM SEARCH																											
Ford	Explorer	2003 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2003 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2003 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2003 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2003 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2003 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2003 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2002 MY	SYSTEM SEARCH																											
Ford	Explorer	2002 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2002 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2002 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2002 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2002 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2002 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2002 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2001 MY	SYSTEM SEARCH																											
Ford	Explorer	2001 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2001 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2001 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2001 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer	2001 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2001 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	SYSTEM SEARCH																											
Ford	Explorer	2000 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2000 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2000 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	2000 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2000 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	1999 MY	SYSTEM SEARCH																											
Ford	Explorer	1999 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1999 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1999 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1999 MY	PAM(Parking Aid Module)																											
Ford	Explorer	1998 MY	SYSTEM SEARCH																											
Ford	Explorer	1998 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1998 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1998 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1998 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1997 MY	SYSTEM SEARCH																											
Ford	Explorer	1997 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1997 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1997 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1997 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer SportTrac	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer SportTrac	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer SportTrac	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2004 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	RAP(Remote Anti-Theft/Personality Module)																									
Ford	E-Series	5.4L	2V	2004 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2004 ~	VSM(Vehicle Security Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2009 ~	ACM(Audio Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	E-Series	5.4L	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	E-Series	5.4L	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	E-Series	5.4L	2V	2009 ~	IPC(Instrument Panel Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																										
Ford	F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																										
Ford	F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																									
Ford	F150	4.6L(BETA)	3V	SYSTEM SEARCH																										
Ford	F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																										
Ford	F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																										
Ford	F150	4.6L(BETA)	3V	ACM(Audio Control Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																										
Ford	F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																										
Ford	F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																										
Ford	F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	4.6L(BETA)	3V	IC(Instrument Cluster)																										
Ford	F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																										
Ford	F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																										
Ford	F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																										
Ford	F150	4.6L(BETA)	3V	PRB(Power Running Board)																										
Ford	F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																										
Ford	F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																										
Ford	F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																										
Ford	F150	5.0L	TiVCT	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	F150	5.0L	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	5.0L	TiVCT	ACM(Audio Control Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	5.0L	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	5.0L	TiVCT	IC(Instrument Cluster)																										
Ford	F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PRB(Power Running Board)																										
Ford	F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	5.0L	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	5.0L	TiVCT	TCM(Transmission Control Module)																										
Ford	F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	F150	5.4L	3V	2009 ~	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2009 ~	PRB(Power Running Board)																									
Ford	F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	6.2L(BETA)	2V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																										
Ford	F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																										
Ford	F150	6.2L(BETA)	2V	ACM(Audio Control Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																										
Ford	F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																										
Ford	F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																										
Ford	F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																										
Ford	F150	6.2L(BETA)	2V	IC(Instrument Cluster)																										
Ford	F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																										
Ford	F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																										
Ford	F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																										
Ford	F150	6.2L(BETA)	2V	PRB(Power Running Board)																										
Ford	F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																										
Ford	F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																										
Ford	F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																										
Ford	F150	Other	2004 ~ 2008	SYSTEM SEARCH																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																										
Ford	F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																										
Ford	F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																										
Ford	F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	Other	2004 ~ 2008	IC(Instrument Cluster)																										
Ford	F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										
Ford	F250	7.3L	SYSTEM SEARCH																											
Ford	F250	7.3L	PCM(PowerTrain Control Module)																											
Ford	F250	7.3L	ABS(Anti-Lock Brake System)																											
Ford	F250	7.3L	ECS(Electronic Crash Sensor)																											
Ford	F250	7.3L	GEM(Generic Electronic Module)																											
Ford	F250	6.2L	SYSTEM SEARCH																											
Ford	F250	6.2L	PCM(Powertrain Control Module)																											
Ford	F250	6.2L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.2L	ACM(Audio Control Module)																											
Ford	F250	6.2L	APIM(Accessory Protocol Control Module)																											
Ford	F250	6.2L	BCMii(Body Control Module)																											
Ford	F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																											
Ford	F250	6.2L	DSM(Driver Seat Module)																											
Ford	F250	6.2L	GPSM(Global Positioning System Module)																											
Ford	F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F250	6.2L	IPC(Instrument Panel Control Module)																											
Ford	F250	6.2L	PAM(Parking Aid Module)																											
Ford	F250	6.2L	RCM(Restraint Control Module)																											
Ford	F250	6.2L	SCCM(Streering Colume Control Module)																											
Ford	F250	6.2L	TBC(Trailer Brake Control Module)																											
Ford	F250	6.2L	TCCM(Transfer Case Control Module)																											
Ford	F250	6.2L	TPM(Tire Pressure Monitor)																											
Ford	F250	6.0L	SYSTEM SEARCH																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.0L	GEM(Generic Electronic Module)																											
Ford	F250	6.0L	HEC(Hybrid Electrical Cluster)																											
Ford	F250	6.0L	OTC(Overhead Trip Computer)																											
Ford	F250	6.0L	PAM(Parking Aid Module)																											
Ford	F250	6.0L	PATS(Passive Anti Theft System)																											
Ford	F250	6.0L	RCM(Restraint Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	VSM(Vehicle Security Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SYSTEM SEARCH																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM(PowerTrain Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4(4x4 Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS(Anti-Lock Brake System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM(Audio Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM(Auxiliary Heater Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM(Accessory Protocol Interface Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM(Circuit Deactivation Ignition Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM(Driver's Seat Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GPSM(Global Positioning System Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC(Instrument Cluster)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM(Parking Aid Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM(Restraint Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM(Rear Entertainment Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS(Satellite Digital Audio Receiver System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC(Trailer Brake Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM(Transmission Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																									
Ford	Fiesta	1.4L	DURATEC 16V	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Fiesta	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	BCMii(Body Control Module)																										
Ford	Fiesta	1.6L	DURATEC	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	BCM(Body Control Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Fiesta	1.6L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.6L	TiVCT	VSM(Vehicle Security Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	Zetec Rocam	IC(Instrument Cluster)																										
Ford	Fiesta	1.6L	Zetec Rocam	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	RKE(Remote Keyless Entry)																										
Ford	Fiesta	1.6L	Zetec Rocam	TCM(Transmission Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	SYSTEM SEARCH																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																										
Ford	Fiesta	2.0L	SYSTEM SEARCH																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	2.0L	ACM(Audio Control Module)																											
Ford	Fiesta	2.0L	EATC(Electronic Automatic Temperature Control)																											
Ford	Fiesta	2.0L	GEM(Generic Electronic Module)																											
Ford	Fiesta	2.0L	IC(Instrument Cluster)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	RCM(Restraint Control Module)																											
Ford	Fiesta	2.0L	PATS(Passive Anti Theft System)-BETA																											
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Focus	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	ZETEC ROCAM	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Focus	1.6L	ZETEC ROCAM	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Focus	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic power steering)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ACM(Audio control module)																										
Ford	Focus	1.8L	DURATEC HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.8L	DURATEC HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.8L	DURATEC HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.8L	DURATEC HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.8L	DURATEC HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	IC(Instrument cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	NAV(Navigation System)																										
Ford	Focus	1.8L	DURATEC HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	MC(Message Center)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FDIM(Front Display Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TCM(Transmission control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CSM(Central Security Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EPS(Electronic power steering)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GDM(Generic Display Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	NAV(Navigation System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RKE(Remote Keyless Entry)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TBM(Tracking And Blocking Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SRM(Speech recognition module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SYSTEM SEARCH																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ACM(Audio Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	BCM(Body Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DDM(Driver's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	IPC(Instrument Panel Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PAM(Parking Aid Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PSCM(Power Steering Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SASM(Steering Angle Sensor Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	ABS(Anti-Lock Brake System)		V	V																							
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Focus	2.0L DIESEL	2003 ~ 2008	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FACM(Fuel Additive Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RETM(Rear Entertainment Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RKE(Remote Keyless Entry)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	TCM(Transmission control module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	DDM(Driver's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	MC(Message Center)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ACM(Audio control module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)				V	V	V	V	V	V	V	V	V														
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)													V													
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)														V												
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Focus C-MAX	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Flex	3.5L	4V	SYSTEM SEARCH																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	4V	ACM(Audio control module)																										
Ford	Flex	3.5L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	4V	DDM(Driver's Door Module)															V											
Ford	Flex	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	4V	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	4V	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	4V	IC(Instrument cluster)																										
Ford	Flex	3.5L	4V	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	4V	LTM(Liftgate/Trunk Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Flex	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	4V	Factory Keyless Entry Code																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio control module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)															V											
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC(Instrument cluster)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Flex	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	TiVCT	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Flex	3.5L	TiVCT	ACM(Audio control module)																										
Ford	Flex	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	TiVCT	DDM(Driver's Door Module)															V											
Ford	Flex	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	TiVCT	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	TiVCT	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	TiVCT	IC(Instrument cluster)																										
Ford	Flex	3.5L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	TiVCT	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																	V	V									
Ford	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Ford	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																	V	V									
Ford	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Ford	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Ford	Freestyle	3.0L	4V	SYSTEM SEARCH																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Freestyle	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Freestyle	3.0L	4V	ACM(Audio Control Module)																										
Ford	Freestyle	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Freestyle	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Freestyle	3.0L	4V	GEM(Generic Electronic Module)																		V								
Ford	Freestyle	3.0L	4V	IC(Instrument Cluster)																										
Ford	Freestyle	3.0L	4V	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Freestyle	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Freestyle	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Five Hundred	3.0L	4V	SYSTEM SEARCH																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Five Hundred	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Five Hundred	3.0L	4V	ACM(Audio Control Module)																										
Ford	Five Hundred	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Five Hundred	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Five Hundred	3.0L	4V	GEM(Generic Electronic Module)																		V								
Ford	Five Hundred	3.0L	4V	IC(Instrument Cluster)																										
Ford	Five Hundred	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Five Hundred	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Five Hundred	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Ford GT	5.4L	4V	SYSTEM SEARCH																										
Ford	Ford GT	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	IC(Instrument Cluster)																										
Ford	Ford GT	5.4L	4V	PATS(Passive Anti Theft System)																										
Ford	Ford GT	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	TCM(Transmission control module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Fusion	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	DURATEC	IC(Instrument cluster)																										
Ford	Fusion	1.6L	DURATEC	ACM(Audio control module)																										
Ford	Fusion	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fusion	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																			V	V						
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																			V	V						
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SYSTEM SEARCH																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																			V	V						
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BCM(Body Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	C-CM(Cruise Control Module)																					V					
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																						V				
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																							V			
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HUD(Head Up Display)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM(Secondary OBD Control Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	TCU(Telematic Control Unit Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																							V	V		
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Fusion	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										V
Ford	Fusion	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.5L	IVCT	SYSTEM SEARCH																										
Ford	Fusion	2.5L	IVCT	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	IVCT	ABS(Anti-Lock Brake System)																			V	V						
Ford	Fusion	2.5L	IVCT	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	IVCT	BCM(Body Control Module)																										
Ford	Fusion	2.5L	IVCT	C-CM(Cruise Control Module)																					V					
Ford	Fusion	2.5L	IVCT	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.5L	IVCT	DDM(Driver's Door Module)																										
Ford	Fusion	2.5L	IVCT	DSM(Driver's Seat Module)																										
Ford	Fusion	2.5L	IVCT	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	IVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.5L	IVCT	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	IVCT	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	IVCT	GWM(Gateway Module A)																										
Ford	Fusion	2.5L	IVCT	HUD(Head Up Display)																										
Ford	Fusion	2.5L	IVCT	IPC(Instrument Panel Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Fusion	2.5L	IVCT	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.5L	IVCT	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	IVCT	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	IVCT	PDM(Passenger's Door Module)																										
Ford	Fusion	2.5L	IVCT	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	IVCT	RACM(Rear Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	IVCT	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.5L	IVCT	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.5L	IVCT	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.5L	IVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	IVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	TCM(Transmission Control Module)																								V	V	
Ford	Fusion	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.0L	4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Fusion	3.5L	4V	SYSTEM SEARCH																										
Ford	Fusion	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.5L	4V	TCM(Transmission Control Module)																								V	V	
Ford	Fusion	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.5L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.5L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.5L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.5L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	KA	2000 MY	SYSTEM SEARCH																											
Ford	KA	2000 MY	PCM(PowerTrain Control Module)																											
Ford	KA	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	KA	2000 MY	RCM(Restraint Control Module)																											
Ford	KA	1999 MY	PCM(PowerTrain Control Module)																											
Ford	KA	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Kuga	2.0L DIESEL	SYSTEM SEARCH																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)						V	V	V	V	V	V	V															
Ford	Kuga	2.0L DIESEL	TCM(Transmission Control Module)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)		V																									
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																											
Ford	Kuga	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																											
Ford	Kuga	2.0L DIESEL	AWD(All Wheel Drive Module)																											
Ford	Kuga	2.0L DIESEL	BCMii(Body Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Kuga	2.0L DIESEL	CCMii(Cruise Control Module)																											
Ford	Kuga	2.0L DIESEL	CMR(Camera Module Rear)																											
Ford	Kuga	2.0L DIESEL	D_DCU(Driver Door Control Unit)																											
Ford	Kuga	2.0L DIESEL	DDM(Driver's Door Module)																											
Ford	Kuga	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Kuga	2.0L DIESEL	EPS(Electronic Power Steering)																											
Ford	Kuga	2.0L DIESEL	FDSM(Front Distance Sensing Module)																											
Ford	Kuga	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																											
Ford	Kuga	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Kuga	2.0L DIESEL	GEM(Generic Electronic Module)																											
Ford	Kuga	2.0L DIESEL	GPSM(Global Positioning System Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Kuga	2.0L DIESEL	IPM-A(Image Processing Module A)																											
Ford	Kuga	2.0L DIESEL	IPM-B(Image Processing Module B)																											
Ford	Kuga	2.0L DIESEL	IPC(Instrument Panel Control Module)																											
Ford	Kuga	2.0L DIESEL	IC(Instrument Cluster)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PSCM(Power Steering Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RFA(Remote Function Actuator)																											
Ford	Kuga	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																											
Ford	Kuga	2.0L DIESEL	RETM(Rear Entertainment Module)																											
Ford	Kuga	2.0L DIESEL	SASM(Steering Angle Sensor Module)																											
Ford	Kuga	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Kuga	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Kuga	2.0L DIESEL	SRM(Speech Recognition Module)																											
Ford	Kuga	2.0L DIESEL	TRM(Trailer Module)																											
Ford	Kuga	2.5L	I5	SYSTEM SEARCH																										
Ford	Kuga	2.5L	I5	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.5L	I5	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.5L	I5	ACM(Audio Control Module)																										
Ford	Kuga	2.5L	I5	AWD(All Wheel Drive Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Kuga	2.5L	I5	CMR(Camera Module Rear)																										
Ford	Kuga	2.5L	I5	D_DCU(Driver Door Control Unit)																										
Ford	Kuga	2.5L	I5	EATC(Electronic Automatic Temperature Control)																										
Ford	Kuga	2.5L	I5	EPS(Electronic Power Steering)																										
Ford	Kuga	2.5L	I5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Kuga	2.5L	I5	GEM(Generic Electronic Module)																										
Ford	Kuga	2.5L	I5	HCM(Headlamp Control Module)																										
Ford	Kuga	2.5L	I5	IC(Instrument Cluster)																										
Ford	Kuga	2.5L	I5	PAM(Parking Aid Module)																										
Ford	Kuga	2.5L	I5	PDM(Passenger's Door Module)																										
Ford	Kuga	2.5L	I5	RCM(Restraint Control Module)																										
Ford	Kuga	2.5L	I5	RETM(Rear Entertainment Module)																										
Ford	Kuga	2.5L	I5	RKE(Remote Keyless Entry)																										
Ford	Kuga	2.5L	I5	SRM(Speech Recognition Module)																										
Ford	Kuga	2.5L	I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)												V														
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Mondeo	2010 MY	2.5L I5	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.5L I5	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.5L I5	AHCM(Auxiliary Heater Control Module)													V													
Ford	Mondeo	2010 MY	2.5L I5	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.5L I5	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.5L I5	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.5L I5	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.5L I5	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.5L I5	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SYSTEM SEARCH																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	AHCM(Auxiliary Heater Control Module)													V													

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	BCMii(Body Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CCMii(Cruise Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DDM(Driver's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DSM(Driver's Seat Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HCM(HeadLamp Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RFA(Remote Function Actuator)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TRM(Trailer Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ACM(Audio Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	CDP(Compact Disc Player)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GDM(Generic Display Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	NAV(Navigation System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SRM(Speech Recognition Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	SYSTEM SEARCH																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	GEM(Generic Electronic Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	HCM(Headlamp Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2000 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	2000 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	2000 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1999 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1999 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Mondeo	1998 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1998 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1998 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1997 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1997 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1997 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1997 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	BCM-B(Body Control Module B)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Mustang	3.7L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Mustang	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Mustang	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Mustang	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Mustang	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Mustang	3.7L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.8L	SYSTEM SEARCH																											
Ford	Mustang	3.8L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.8L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.8L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.8L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.8L	RCM(Restraint Control Module)																											
Ford	Mustang	3.9L	SYSTEM SEARCH																											
Ford	Mustang	3.9L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.9L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.9L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.9L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.9L	RCM(Restraint Control Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	BCM-B(Body Control Module B)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.0L	V6 (SOHC)	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.0L	V6 (SOHC)	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Mustang	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Mustang	4.0L	V6 (SOHC)	PAM(Parking Aid Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PSCM(Power Steering Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Mustang	4.0L	V6 (SOHC)	PATS(Passive Anti Theft System)-BETA																										
Ford	Mustang	4.6L	3V	SYSTEM SEARCH																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	BCM-B(Body Control Module B)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																		V								
Ford	Mustang	4.6L	3V	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	PATS(Passive Anti Theft System)-BETA																										
Ford	Mustang	5.0L	~ 2014	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FDIM(Front Display Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM(Body Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	C-CM(Cruise Control Module)																				V					
Ford	Mustang	5.0L	2015 ~	TiVCT	DACM-C(Digital Audio Control Module C)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DDM(Driver's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSM(Driver's Seat Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCIM(Front Controls Interface Module)																					V				
Ford	Mustang	5.0L	2015 ~	TiVCT	GPSM(Global Positioning System Module)																						V			
Ford	Mustang	5.0L	2015 ~	TiVCT	GWM(Gateway Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	HUD(Head Up Display)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ICM(Information Center Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	IPC(Instrument Panel Control Module)																									V
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-A(Movable Roof Control Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-B(Movable Roof Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PAM(Parking Aid Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PDM(Passenger's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Mustang	5.0L	2015 ~	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	RTM(Radio Transceiver Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCM-E(Seat Control Module E)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Mustang	5.4L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	BCM-B(Body Control Module B)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.4L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.4L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.4L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.4L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.4L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.4L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	BCM-B(Body Control Module B)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.8L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.8L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.8L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.8L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.8L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.8L	4V	PAM(Parking Aid Module)																										
Ford	Mustang	5.8L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM-B(Body Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																				V						
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																					V					
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																						V				
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ICM(Information Center Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										V
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-A(Movable Roof Control Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-B(Movable Roof Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)				V	V	V		V	V	V	V	V														
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Diesel(WL-CD)	SYSTEM SEARCH																											
Ford	Ranger	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.0 Diesel(WE-CD)	SYSTEM SEARCH																											
Ford	Ranger	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Ranger	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)				V	V	V		V	V	V	V	V														
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Gasoline	SYSTEM SEARCH																											
Ford	Ranger	2.5 Gasoline	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Gasoline	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Gasoline	ACM(Audio Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Ranger	2.5 Gasoline	BCMii(Body Control Module)																											
Ford	Ranger	2.5 Gasoline	DDM(Driver's Door Module)																											
Ford	Ranger	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																											
Ford	Ranger	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Ranger	2.5 Gasoline	IPC(Instrument Panel Control Module)																											
Ford	Ranger	2.5 Gasoline	PAM(Parking Aid Module)																											
Ford	Ranger	2.5 Gasoline	PDM(Passenger's Door Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	SRM(Speech Recognition Module)																											
Ford	Ranger	2.5 Gasoline	TBM(Tracking And Blocking Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TRM(Trailer Module)																											
Ford	Ranger	2.5 Gasoline	PATS(Passive Anti Theft System)-BETA																											
Ford	Ranger	3.0L	Other	SYSTEM SEARCH																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	Other	IC(Instrument Cluster)																										
Ford	Ranger	3.0L	Other	OCSM(Occupant Classification System Module)																										
Ford	Ranger	3.0L	Other	4X4(4x4 Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	3.0L	FFV	SYSTEM SEARCH																										
Ford	Ranger	3.0L	FFV	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	FFV	PATS(Passive Anti Theft System)																										
Ford	Ranger	3.0L	FFV	RAP(Remote Anti-Theft/Personality Module)																										
Ford	Ranger	3.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Ranger	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Ranger	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Ranger	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Ranger	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	4X4(4x4 Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	IC(Instrument Cluster)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	LTM(Liftgate/Trunk Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SECM(Steering Effort Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DDM(Driver's Door Module)														V											
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HUD(Head Up Display)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	BCM(Body Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DDM(Driver's Door Module)														V											
Ford	Taurus	3.5L	TiVCT	2013 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Taurus	3.5L	TiVCT	2013 ~	GFM(Generic Function Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RACM(Rear Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SCCM(Steering Column Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DDM(Driver's Door Module)														V											
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.0L	2000 ~	SYSTEM SEARCH																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	2000 ~	EATC(Electronic Automatic Temperature Control)																										
Ford	Taurus	3.0L	2000 ~	GEM(Generic Electronic Module)																										
Ford	Taurus	3.0L	2000 ~	IC(Instrument Cluster)																										
Ford	Taurus	3.0L	2000 ~	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	SYSTEM SEARCH																										
Ford	Taurus	3.0L	~ 1999	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	~ 1999	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	~ 1999	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	RIM(Remote Immobilizer Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)															V											
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SYSTEM SEARCH																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PCM(PowerTrain Control Module)							V																			
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ABS(Anti-Lock Brake System)		V																								
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ACM(Audio Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	GEM(Generic Electronic Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	IC(Instrument Cluster)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PAM(Parking Aid Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	RCM(Restraint Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SRM(Speech Recognition Module)																										
Ford	Transit	2.0L	2001 ~ 2004	SYSTEM SEARCH																										
Ford	Transit	2.0L	2001 ~ 2004	PCM(PowerTrain Control Module)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.0L	2001 ~ 2004	ASM(Auto Shift Manual)																										
Ford	Transit	2.0L	2001 ~ 2004	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.0L	2001 ~ 2004	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)			V				V																			

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)				V			V																			
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	CSM(Central Security Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2006.5	PCM(PowerTrain Control Module)				V			V																			
Ford	Transit	2.4L DIESEL	2006.5	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2006.5	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	2.4L DIESEL	2006.5	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	PAM(Parking Aid Module)																										
Ford	Transit	2.4L DIESEL	2006.5	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	TBM(Tracking And Blocking Module)																										
Ford	Transit	2.5L DIESEL	SYSTEM SEARCH																											
Ford	Transit	2.5L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	ASM(Auto Shift Manual)																											
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																										
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Transit	2.5L DIESEL	RCM(Restraint Control Module)																											
Ford	Transit	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Transit	2.5L DIESEL	CSM(Central Security Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	RIM(Remote Immobilizer Module)																											
Ford	Transit	2.5L DIESEL	ACM(Audio Control Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)				V			V																			
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Transit	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Transit	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Transit	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Transit	3.7L	TiVCT	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.7L	TiVCT	BCM(Body Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Ford	Transit	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Transit	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.7L	TiVCT	IPM-A(Image Processing Module A)																										
Ford	Transit	3.7L	TiVCT	IPM-B(Image Processing Module B)																										
Ford	Transit	3.7L	TiVCT	PAM(Park Aid Module)																										
Ford	Transit	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Transit	3.7L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.7L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.7L	TiVCT	TRM(Trailer Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)							V																			
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)		V																								
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Thunderbird	3.9L	4V	SYSTEM SEARCH																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ACM(Audio Control Module)																										
Ford	Thunderbird	3.9L	4V	DDM(Driver's Door Module)																										
Ford	Thunderbird	3.9L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Thunderbird	3.9L	4V	GEM(Generic Electronic Module)																										
Ford	Thunderbird	3.9L	4V	HEC(Hybrid Electrical Cluster)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	REM(Rear Electronic Module)																										
Lincoln	Aviator	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Aviator	4.6L	4V	PCM(Powertrain Control Module)																										
Lincoln	Aviator	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Aviator	4.6L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Aviator	4.6L	4V	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	Aviator	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Aviator	4.6L	4V	IC(Instrument Cluster)																										
Lincoln	Aviator	4.6L	4V	PAM(Parking Aid Module)																										
Lincoln	Aviator	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Aviator	4.6L	4V	TPM(Tire Pressure Monitor)																										
Lincoln	Aviator	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Lincoln	Aviator	4.6L	4V	VSM(Vehicle Security Module)																										
Lincoln	Continental	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Continental	4.6L	4V	PCM(PowerTrain Control Module)																										
Lincoln	Continental	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Continental	4.6L	4V	ACM(Audio Control Module)																										
Lincoln	Continental	4.6L	4V	CPM(Cellular Phone Module)																										
Lincoln	Continental	4.6L	4V	DDM(Driver's Door Module)																										
Lincoln	Continental	4.6L	4V	DSM(Driver's Seat Module)																										
Lincoln	Continental	4.6L	4V	LCM(Lighting Control Module)																										
Lincoln	Continental	4.6L	4V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Continental	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Continental	4.6L	4V	VDM(Vehicle Dynamic Module)																										
Lincoln	Continental	4.6L	4V	VIC(Virtual Image Cluster)																										
Lincoln	Continental	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Continental	4.6L	4V	PATS(Passive Anti Theft System)																										
Lincoln	LS	ALL	SYSTEM SEARCH																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	ABS(Anti-Lock Brake System)																	V	V									
Lincoln	LS	ALL	DCSM(Driver-Dual Climate Control Seat Module)																											
Lincoln	LS	ALL	DDM(Driver's Door Module)																											
Lincoln	LS	ALL	DSM(Driver's Seat Module)																											
Lincoln	LS	ALL	EPB(Electronic Parking Brake)																											
Lincoln	LS	ALL	PAM(Parking Aid Module)																											
Lincoln	LS	ALL	RCM(Restraint Control Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	SCLM(Steering Column Locking Module)																											
Lincoln	LS	ALL	EATC(Electronic Automatic Temperature Control)																											
Lincoln	LS	ALL	GEM(Generic Electronic Module)																											
Lincoln	LS	ALL	HEC(Hybrid Electrical Cluster)																											
Lincoln	LS	ALL	PCSM(Passenger Climate Control Seat Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	MKS	3.7L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKS	3.7L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DDM(Driver's Door Module)														V											
Lincoln	MKS	3.7L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.7L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2009	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2009	IPC(Instrument Panel Control Module)																									V
Lincoln	MKS	3.7L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2009	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2010 ~	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2010 ~	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DDM(Driver's Door Module)														V											
Lincoln	MKS	3.7L	4V	2010 ~	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	MKS	3.7L	4V	2010 ~	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2010 ~	HUD(Head Up Display)																									
Lincoln	MKS	3.7L	4V	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2010 ~	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM(Driver's Door Module)														V											
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM(Driver's Door Module)														V											
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DDM(Driver's Door Module)														V											
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKX	3.5L	4V	2007	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2007	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2007	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2007	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2007	EATC(Electronic Automatic Temperature Control)																									
Lincoln	MKX	3.5L	4V	2007	GEM(Generic Electronic Module)																									
Lincoln	MKX	3.5L	4V	2007	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2007	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2007	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2007	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2007	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2007	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2007	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2007	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2007	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2008	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2008	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2008	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2008	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2008	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2008	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	MKX	3.5L	4V	2008	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2008	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2008	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2008	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2008	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2008	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2008	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2008	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2008	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2009	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2009	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2009	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2009	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2009	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2010	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2010	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2010	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	MKX	3.5L	4V	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2010	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2010	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2010	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2010	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2010	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2010	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2010	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKZ	3.0L	2006	SYSTEM SEARCH																										
Lincoln	MKZ	3.0L	2006	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.0L	2006	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.0L	2006	ACM(Audio Control Module)																										
Lincoln	MKZ	3.0L	2006	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.0L	2006	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.0L	2006	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.0L	2006	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.0L	2006	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.0L	2006	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.0L	2006	IC(Instrument Cluster)																										
Lincoln	MKZ	3.0L	2006	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.0L	2006	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.0L	2006	TCM(Transmission Control Module)																							V	V		
Lincoln	MKZ	3.5L	2007	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2007	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2007	TCM(Transmission Control Module)																							V	V		
Lincoln	MKZ	3.5L	2007	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2007	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2007	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2007	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2007	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2007	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	MKZ	3.5L	2007	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2007	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.5L	2007	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.5L	2007	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2007	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2007	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2007	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2007	PATS(Passive Anti Theft System)																										
Lincoln	MKZ	3.5L	2008	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2008	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2008	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2008	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2008	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2008	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2008	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2008	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2008	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2008	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2008	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2008	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2008	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2008	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2008	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2008	TCM(Transmission Control Module)																							V	V		
Lincoln	MKZ	3.5L	2009	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2009	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2009	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2009	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2009	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2009	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2009	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2009	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2009	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	MKZ	3.5L	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2009	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2009	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2009	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2009	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2009	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2009	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2009	TCM(Transmission Control Module)																							V	V		
Lincoln	MKZ	3.5L	2010	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2010	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2010	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2010	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2010	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2010	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2010	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2010	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2010	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	3.5L	2010	FDIM(Front Display Interface Module)																										
Lincoln	MKZ	3.5L	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2010	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	3.5L	2010	HCM(Headlamp Control Module)																										
Lincoln	MKZ	3.5L	2010	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2010	ILCM(Interior Lighting Control Module)																										
Lincoln	MKZ	3.5L	2010	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	3.5L	2010	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2010	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2010	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2010	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	3.5L	2010	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	3.5L	2010	TCM(Transmission Control Module)																							V	V		
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																					V					
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																						V				
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																							V			
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										V
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRCM(Transmission Range Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM(Body Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM(Cruise Control Module)																					V					
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																						V				
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																							V			
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										V
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM(Transmission Range Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Lincoln	Navigator	2007 ~	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	APIM(Accessory Protocol Interface Module)																										
Lincoln	Navigator	2007 ~	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GPSM(Global Positioning System Module)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	2007 ~	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	2007 ~	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	2007 ~	5.4L	PRB(Power Running Board)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCU(Audio Rear Control Unit)																										
Lincoln	Navigator	2007 ~	5.4L	RETM(Rear Entertainment Module)																										
Lincoln	Navigator	2007 ~	5.4L	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	Navigator	2007 ~	5.4L	TCCM(Transfer Case Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	TCM(Transmission Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	2007 ~	5.4L	4X4(4x4 Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PATS(Passive Anti Theft System)																										
Lincoln	Navigator	~ 2007	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	GEM(Generic Electronic Module)																										
Lincoln	Navigator	~ 2007	5.4L	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Navigator	~ 2007	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	~ 2007	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	~ 2007	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	~ 2007	5.4L	RIM(Remote Immobilizer Module)																										
Lincoln	Navigator	~ 2007	5.4L	VSM(Vehicle Security Module)																										
Lincoln	Town Car	4.6L	2V	SYSTEM SEARCH																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	LCM(Lighting Control Module)																										
Lincoln	Town Car	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Lincoln	Town Car	4.6L	2V	DDM(Driver's Door Module)																										
Lincoln	Town Car	4.6L	2V	DSM(Driver's Seat Module)																										
Lincoln	Town Car	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Town Car	4.6L	2V	RATC(Rear Air Temperature Control)																										
Lincoln	Town Car	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Lincoln	Town Car	4.6L	2V	PAM(Parking Aid Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	HEC(Hybrid Electrical Cluster)																										
Lincoln	Town Car	4.6L	2V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Town Car	4.6L	2V	RASM(Rear Air Suspension Module)																										
Mercury	Grand Marquis	4.6L	2V	SYSTEM SEARCH																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	DDM(Driver's Door Module)																										
Mercury	Grand Marquis	4.6L	2V	IC(Instrument Cluster)																										
Mercury	Grand Marquis	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Grand Marquis	4.6L	2V	LCM(Lighting Control Module)																										
Mercury	Grand Marquis	4.6L	2V	MC(Message Center)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RIM(Remote Immobilizer Module)																										
Mercury	Grand Marquis	4.6L	2V	GEM(Generic Electronic Module)																										
Mercury	Grand Marquis	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Mercury	Marauder	4.6L	4V	SYSTEM SEARCH																										
Mercury	Marauder	4.6L	4V	PCM(Powertrain Control Module)																										
Mercury	Marauder	4.6L	4V	ABS(Anti-Lock Brake System)																V	V									
Mercury	Marauder	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Marauder	4.6L	4V	RASM(Rear Air Suspension Module)																										
Mercury	Marauder	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Mercury	Marauder	4.6L	4V	DDM(Driver's Door Module)																										
Mercury	Marauder	4.6L	4V	LCM(Lighting Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										V
Mercury	Milan	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	Milan	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SYSTEM SEARCH																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Milan	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	Milan	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										V
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Milan	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	3.0L	4V	TCM(Transmission Control Module)																							V	V		
Mercury	Milan	3.0L	4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Milan	3.0L	4V	PATS(Passive Anti Theft System)																										
Mercury	Montego	3.0L	4V	SYSTEM SEARCH																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Montego	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Montego	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Montego	3.0L	4V	DSM(Driver's Seat Module)																										
Mercury	Montego	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Montego	3.0L	4V	GEM(Generic Electronic Module)																		V								
Mercury	Montego	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Montego	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Montego	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Montego	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																	V	V									
Mercury	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Mercury	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																	V	V									
Mercury	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Mercury	Mountaineer	2010 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2010 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2010 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2010 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2010 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2010 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.6L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	Mountaineer	2009 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2009 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2009 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2009 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2009 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2008 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2008 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2008 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2008 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	Mountaineer	2007 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2007 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2007 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2007 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2007 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2006 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2006 MY	4.6L	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	Mountaineer	2006 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2006 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2006 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2006 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2006 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2003 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2003 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2003 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2003 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2003 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2003 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2003 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2002 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2002 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2002 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2002 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	Mountaineer	2002 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2002 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2001 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2001 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2001 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2001 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2001 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2001 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2000 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2000 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2000 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2000 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2000 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2000 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	1999 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1999 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1999 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1999 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1999 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1999 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	1998 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1998 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1998 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1998 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1998 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1997 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1997 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1997 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1997 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1997 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Auxiliary vehicle ID reset	ABS/EPS Service Bleed	Fuel injector correction factors	DPF Static Regeneration	Reset the Diesel Particulate Filter Learned Values	Reset the water in fuel warning indicator	Reset the Exhaust Gas Temperature Value	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	Prime the Fuel System	Beltminder Enable/Disable	DDM Module Installation	Yaw Rate/Lateral Acceleration Calibration	Brake Booster/Steering Wheel Angle Sensor Calibration	GEM Module Installation	EIPB Apply and Release Test	EIPB Maintenance Mode	CCMii Sensor Alignment	FCIM Module Installation	GPSM Module Installation	Reset Transmission Adaptive Shifting Learned Values	Neutral Position Learning	IPC Module Installation
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Vehicle Info.	Vehicle Info.	Vehicle Info.																												
Ford	Crown Victoria	4.6L	2V	SYSTEM SEARCH																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	DDM(Driver's Door Module)																										
Ford	Crown Victoria	4.6L	2V	IC(Instrument Cluster)																										
Ford	Crown Victoria	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Crown Victoria	4.6L	2V	LCM(Lighting Control Module)																										
Ford	Crown Victoria	4.6L	2V	MC(Message Center)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	Crown Victoria	4.6L	2V	GEM(Generic Electronic Module)																										
Ford	Crown Victoria	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.4L	DIESEL	SYSTEM SEARCH																										
Ford	Ecosport	1.4L	DIESEL	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.4L	DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.4L	DIESEL	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.4L	DIESEL	IC(Instrument Cluster)																										
Ford	Ecosport	1.4L	DIESEL	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	FFV	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Ecosport	1.6L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	FFV	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Escort	2.0L	SYSTEM SEARCH																											
Ford	Escort	2.0L	PCM(PowerTrain Control Module)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ECS(Electronic Crash Sensor)																											
Ford	Escort	2.0L	PATS(Passive Anti Theft System)																											
Ford	Escort	2.0L	RAP(Remote Anti-Theft/Personality Module)																											
Ford	Edge	3.5L	4V	SYSTEM SEARCH																										
Ford	Edge	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Edge	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Edge	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Edge	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	4V	IC(Instrument Cluster)																										
Ford	Edge	3.5L	4V	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Edge	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Edge	3.5L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Edge	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.5L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.5L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	TiVCT	RFA(Remote Function Actuator)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Edge	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.5L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.5L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Edge	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.7L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.7L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.7L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.7L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.7L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.7L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Edge	3.7L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.7L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.7L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.7L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.7L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.7L	TiVCT	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.7L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Escape	Up to 2004	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Escape	Up to 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	Up to 2004	Immobilizer																											
Ford	Escape	Up to 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	Up to 2004	RCM(Restraint Control Module)																											
Ford	Escape	Up to 2004	GEM(Generic Electronic Module)																											
Ford	Escape	From 2004	SYSTEM SEARCH																											
Ford	Escape	From 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	From 2004	PATS(Passive Anti Theft System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	RCM(Restraint Control Module)																											
Ford	Escape	From 2004	IC(Instrument cluster)																											
Ford	Escape	From 2004	GEM(Generic Electronic Module)																											
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Excursion	GASOLINE	SYSTEM SEARCH																											
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											
Ford	Excursion	GASOLINE	ABS(Anti-Lock Brake System)																											
Ford	Excursion	GASOLINE	CSM(Central Security Module)																											
Ford	Excursion	GASOLINE	DSM(Driver's Seat Module)																											
Ford	Excursion	GASOLINE	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	GASOLINE	ECS(Electronic Crash Sensor)																											
Ford	Excursion	GASOLINE	GEM(Generic Electronic Module)																											
Ford	Excursion	GASOLINE	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	GASOLINE	OTC(Overhead Trip Computer)																											
Ford	Excursion	GASOLINE	PAM(Parking Aid Module)																											
Ford	Excursion	GASOLINE	PATS(Passive Anti Theft System)																											
Ford	Excursion	GASOLINE	TCM(Transmission Control Module)																											
Ford	Excursion	GASOLINE	VSM(Vehicle Security Module)																											
Ford	Excursion	DIESEL	SYSTEM SEARCH																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Excursion	DIESEL	CSM(Central Security Module)																											
Ford	Excursion	DIESEL	DSM(Driver's Seat Module)																											
Ford	Excursion	DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	DIESEL	ECS(Electronic Crash Sensor)																											
Ford	Excursion	DIESEL	GEM(Generic Electronic Module)																											
Ford	Excursion	DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	DIESEL	OTC(Overhead Trip Computer)																											
Ford	Excursion	DIESEL	PAM(Parking Aid Module)																											
Ford	Excursion	DIESEL	PATS(Passive Anti Theft System)																											
Ford	Excursion	DIESEL	TCM(Transmission Control Module)																											
Ford	Excursion	DIESEL	VSM(Vehicle Security Module)																											
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	EATC(Electronic Automatic Temperature Control)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VSM(Vehicle Security Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TBC(Trailer Brake Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCCM(Transfer Case Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	GEM(Generic Electronic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	5.4L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VSM(Vehicle Security Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	APIM(Accessory Protocol Interface Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GPSM(Global Positioning System Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	4.6L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PRB(Power Running Board)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCU(Audio Rear Control Unit)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RETM(Rear Entertainment Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	TCM(Transmission Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	4X4(4x4 Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VSM(Vehicle Security Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2015 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2014 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PATS(Passive Anti Theft System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2012 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2010 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2009 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2005 MY	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2005 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2005 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2005 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2005 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2005 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2004 MY	SYSTEM SEARCH																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2004 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2004 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2004 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2004 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2004 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2003 MY	SYSTEM SEARCH																											
Ford	Explorer	2003 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2003 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2003 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2003 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2003 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2003 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2003 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2002 MY	SYSTEM SEARCH																											
Ford	Explorer	2002 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2002 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2002 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2002 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2002 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2002 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2002 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2001 MY	SYSTEM SEARCH																											
Ford	Explorer	2001 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2001 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2001 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2001 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer	2001 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2001 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	SYSTEM SEARCH																											
Ford	Explorer	2000 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2000 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2000 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	2000 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2000 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	1999 MY	SYSTEM SEARCH																											
Ford	Explorer	1999 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1999 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1999 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1999 MY	PAM(Parking Aid Module)																											
Ford	Explorer	1998 MY	SYSTEM SEARCH																											
Ford	Explorer	1998 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1998 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1998 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1998 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1997 MY	SYSTEM SEARCH																											
Ford	Explorer	1997 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1997 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1997 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1997 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer SportTrac	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer SportTrac	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer SportTrac	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2004 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	RAP(Remote Anti-Theft/Personality Module)																									
Ford	E-Series	5.4L	2V	2004 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2004 ~	VSM(Vehicle Security Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2009 ~	ACM(Audio Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	E-Series	5.4L	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	E-Series	5.4L	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	E-Series	5.4L	2V	2009 ~	IPC(Instrument Panel Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																										
Ford	F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																										
Ford	F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																									
Ford	F150	4.6L(BETA)	3V	SYSTEM SEARCH																										
Ford	F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																										
Ford	F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																										
Ford	F150	4.6L(BETA)	3V	ACM(Audio Control Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																										
Ford	F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																										
Ford	F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																										
Ford	F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	4.6L(BETA)	3V	IC(Instrument Cluster)																										
Ford	F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																										
Ford	F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																										
Ford	F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																										
Ford	F150	4.6L(BETA)	3V	PRB(Power Running Board)																										
Ford	F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																										
Ford	F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																										
Ford	F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																										
Ford	F150	5.0L	TiVCT	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	F150	5.0L	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	5.0L	TiVCT	ACM(Audio Control Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	5.0L	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	5.0L	TiVCT	IC(Instrument Cluster)																										
Ford	F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PRB(Power Running Board)																										
Ford	F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	5.0L	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	5.0L	TiVCT	TCM(Transmission Control Module)																										
Ford	F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	F150	5.4L	3V	2009 ~	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2009 ~	PRB(Power Running Board)																									
Ford	F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	6.2L(BETA)	2V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																										
Ford	F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																										
Ford	F150	6.2L(BETA)	2V	ACM(Audio Control Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																										
Ford	F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																										
Ford	F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																										
Ford	F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																										
Ford	F150	6.2L(BETA)	2V	IC(Instrument Cluster)																										
Ford	F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																										
Ford	F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																										
Ford	F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																										
Ford	F150	6.2L(BETA)	2V	PRB(Power Running Board)																										
Ford	F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																										
Ford	F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																										
Ford	F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																										
Ford	F150	Other	2004 ~ 2008	SYSTEM SEARCH																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																										
Ford	F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																										
Ford	F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																										
Ford	F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	Other	2004 ~ 2008	IC(Instrument Cluster)																										
Ford	F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										
Ford	F250	7.3L	SYSTEM SEARCH																											
Ford	F250	7.3L	PCM(PowerTrain Control Module)																											
Ford	F250	7.3L	ABS(Anti-Lock Brake System)																											
Ford	F250	7.3L	ECS(Electronic Crash Sensor)																											
Ford	F250	7.3L	GEM(Generic Electronic Module)																											
Ford	F250	6.2L	SYSTEM SEARCH																											
Ford	F250	6.2L	PCM(Powertrain Control Module)																											
Ford	F250	6.2L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.2L	ACM(Audio Control Module)																											
Ford	F250	6.2L	APIM(Accessory Protocol Control Module)																											
Ford	F250	6.2L	BCMii(Body Control Module)																											
Ford	F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																											
Ford	F250	6.2L	DSM(Driver Seat Module)																											
Ford	F250	6.2L	GPSM(Global Positioning System Module)																											
Ford	F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F250	6.2L	IPC(Instrument Panel Control Module)																											
Ford	F250	6.2L	PAM(Parking Aid Module)																											
Ford	F250	6.2L	RCM(Restraint Control Module)																											
Ford	F250	6.2L	SCCM(Streering Colume Control Module)																											
Ford	F250	6.2L	TBC(Trailer Brake Control Module)																											
Ford	F250	6.2L	TCCM(Transfer Case Control Module)																											
Ford	F250	6.2L	TPM(Tire Pressure Monitor)																											
Ford	F250	6.0L	SYSTEM SEARCH																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.0L	GEM(Generic Electronic Module)																											
Ford	F250	6.0L	HEC(Hybrid Electrical Cluster)																											
Ford	F250	6.0L	OTC(Overhead Trip Computer)																											
Ford	F250	6.0L	PAM(Parking Aid Module)																											
Ford	F250	6.0L	PATS(Passive Anti Theft System)																											
Ford	F250	6.0L	RCM(Restraint Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	VSM(Vehicle Security Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SYSTEM SEARCH																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM(PowerTrain Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4(4x4 Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS(Anti-Lock Brake System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM(Audio Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM(Auxiliary Heater Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM(Accessory Protocol Interface Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM(Circuit Deactivation Ignition Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM(Driver's Seat Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GPSM(Global Positioning System Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC(Instrument Cluster)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM(Parking Aid Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM(Restraint Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM(Rear Entertainment Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS(Satellite Digital Audio Receiver System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC(Trailer Brake Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM(Transmission Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																									
Ford	Fiesta	1.4L	DURATEC 16V	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Fiesta	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	BCMii(Body Control Module)																										
Ford	Fiesta	1.6L	DURATEC	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	BCM(Body Control Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Fiesta	1.6L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.6L	TiVCT	VSM(Vehicle Security Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	Zetec Rocam	IC(Instrument Cluster)																										
Ford	Fiesta	1.6L	Zetec Rocam	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	RKE(Remote Keyless Entry)																										
Ford	Fiesta	1.6L	Zetec Rocam	TCM(Transmission Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	SYSTEM SEARCH																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																										
Ford	Fiesta	2.0L	SYSTEM SEARCH																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	2.0L	ACM(Audio Control Module)																											
Ford	Fiesta	2.0L	EATC(Electronic Automatic Temperature Control)																											
Ford	Fiesta	2.0L	GEM(Generic Electronic Module)																											
Ford	Fiesta	2.0L	IC(Instrument Cluster)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	RCM(Restraint Control Module)																											
Ford	Fiesta	2.0L	PATS(Passive Anti Theft System)-BETA																											
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Focus	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	ZETEC ROCAM	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Focus	1.6L	ZETEC ROCAM	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Focus	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic power steering)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ACM(Audio control module)																										
Ford	Focus	1.8L	DURATEC HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.8L	DURATEC HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.8L	DURATEC HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.8L	DURATEC HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.8L	DURATEC HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	IC(Instrument cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	NAV(Navigation System)																										
Ford	Focus	1.8L	DURATEC HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	MC(Message Center)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FDIM(Front Display Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TCM(Transmission control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CSM(Central Security Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EPS(Electronic power steering)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GDM(Generic Display Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	NAV(Navigation System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RKE(Remote Keyless Entry)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TBM(Tracking And Blocking Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SRM(Speech recognition module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SYSTEM SEARCH																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ACM(Audio Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	BCM(Body Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DDM(Driver's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	IPC(Instrument Panel Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PAM(Parking Aid Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PSCM(Power Steering Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SASM(Steering Angle Sensor Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Focus	2.0L DIESEL	2003 ~ 2008	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FACM(Fuel Additive Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RETM(Rear Entertainment Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RKE(Remote Keyless Entry)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	TCM(Transmission control module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	DDM(Driver's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	MC(Message Center)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ACM(Audio control module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Focus C-MAX	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Flex	3.5L	4V	SYSTEM SEARCH																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	4V	ACM(Audio control module)																										
Ford	Flex	3.5L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	4V	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	4V	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	4V	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	4V	IC(Instrument cluster)																										
Ford	Flex	3.5L	4V	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	4V	LTM(Liftgate/Trunk Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Flex	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	4V	Factory Keyless Entry Code																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio control module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC(Instrument cluster)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Flex	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	TiVCT	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Flex	3.5L	TiVCT	ACM(Audio control module)																										
Ford	Flex	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	TiVCT	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	TiVCT	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	TiVCT	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	TiVCT	IC(Instrument cluster)																										
Ford	Flex	3.5L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	TiVCT	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Ford	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Ford	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Ford	Freestyle	3.0L	4V	SYSTEM SEARCH																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Freestyle	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Freestyle	3.0L	4V	ACM(Audio Control Module)																										
Ford	Freestyle	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Freestyle	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Freestyle	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Freestyle	3.0L	4V	IC(Instrument Cluster)																										
Ford	Freestyle	3.0L	4V	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Freestyle	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Freestyle	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Five Hundred	3.0L	4V	SYSTEM SEARCH																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Five Hundred	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Five Hundred	3.0L	4V	ACM(Audio Control Module)																										
Ford	Five Hundred	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Five Hundred	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Five Hundred	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Five Hundred	3.0L	4V	IC(Instrument Cluster)																										
Ford	Five Hundred	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Five Hundred	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Five Hundred	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Ford GT	5.4L	4V	SYSTEM SEARCH																										
Ford	Ford GT	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	IC(Instrument Cluster)																										
Ford	Ford GT	5.4L	4V	PATS(Passive Anti Theft System)																										
Ford	Ford GT	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	TCM(Transmission control module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Fusion	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	DURATEC	IC(Instrument cluster)																										
Ford	Fusion	1.6L	DURATEC	ACM(Audio control module)																										
Ford	Fusion	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fusion	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SYSTEM SEARCH																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BCM(Body Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HUD(Head Up Display)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM(Secondary OBD Control Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	TCU(Telematic Control Unit Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Fusion	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.5L	IVCT	SYSTEM SEARCH																										
Ford	Fusion	2.5L	IVCT	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	IVCT	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	IVCT	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	IVCT	BCM(Body Control Module)		V																								
Ford	Fusion	2.5L	IVCT	C-CM(Cruise Control Module)																										
Ford	Fusion	2.5L	IVCT	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.5L	IVCT	DDM(Driver's Door Module)																										
Ford	Fusion	2.5L	IVCT	DSM(Driver's Seat Module)																										
Ford	Fusion	2.5L	IVCT	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	IVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.5L	IVCT	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	IVCT	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	IVCT	GWM(Gateway Module A)																										
Ford	Fusion	2.5L	IVCT	HUD(Head Up Display)																										
Ford	Fusion	2.5L	IVCT	IPC(Instrument Panel Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Fusion	2.5L	IVCT	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.5L	IVCT	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	IVCT	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	IVCT	PDM(Passenger's Door Module)																										
Ford	Fusion	2.5L	IVCT	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	IVCT	RACM(Rear Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	IVCT	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.5L	IVCT	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.5L	IVCT	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.5L	IVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	IVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.0L	4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Fusion	3.5L	4V	SYSTEM SEARCH																										
Ford	Fusion	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.5L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.5L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.5L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.5L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.5L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	KA	2000 MY	SYSTEM SEARCH																											
Ford	KA	2000 MY	PCM(PowerTrain Control Module)																											
Ford	KA	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	KA	2000 MY	RCM(Restraint Control Module)																											
Ford	KA	1999 MY	PCM(PowerTrain Control Module)																											
Ford	KA	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Kuga	2.0L DIESEL	SYSTEM SEARCH																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)				V	V	V	V	V																			
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)									V	V	V	V															
Ford	Kuga	2.0L DIESEL	TCM(Transmission Control Module)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																											
Ford	Kuga	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																											
Ford	Kuga	2.0L DIESEL	AWD(All Wheel Drive Module)																											
Ford	Kuga	2.0L DIESEL	BCMii(Body Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Kuga	2.0L DIESEL	CCMii(Cruise Control Module)																											
Ford	Kuga	2.0L DIESEL	CMR(Camera Module Rear)																											
Ford	Kuga	2.0L DIESEL	D_DCU(Driver Door Control Unit)																											
Ford	Kuga	2.0L DIESEL	DDM(Driver's Door Module)																											
Ford	Kuga	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Kuga	2.0L DIESEL	EPS(Electronic Power Steering)																											
Ford	Kuga	2.0L DIESEL	FDSM(Front Distance Sensing Module)																											
Ford	Kuga	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																											
Ford	Kuga	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Kuga	2.0L DIESEL	GEM(Generic Electronic Module)																											
Ford	Kuga	2.0L DIESEL	GPSM(Global Positioning System Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Kuga	2.0L DIESEL	IPM-A(Image Processing Module A)																											
Ford	Kuga	2.0L DIESEL	IPM-B(Image Processing Module B)																											
Ford	Kuga	2.0L DIESEL	IPC(Instrument Panel Control Module)																											
Ford	Kuga	2.0L DIESEL	IC(Instrument Cluster)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PSCM(Power Steering Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RFA(Remote Function Actuator)																											
Ford	Kuga	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																											
Ford	Kuga	2.0L DIESEL	RETM(Rear Entertainment Module)																											
Ford	Kuga	2.0L DIESEL	SASM(Steering Angle Sensor Module)																											
Ford	Kuga	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Kuga	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Kuga	2.0L DIESEL	SRM(Speech Recognition Module)																											
Ford	Kuga	2.0L DIESEL	TRM(Trailer Module)																											
Ford	Kuga	2.5L	I5	SYSTEM SEARCH																										
Ford	Kuga	2.5L	I5	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.5L	I5	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.5L	I5	ACM(Audio Control Module)																										
Ford	Kuga	2.5L	I5	AWD(All Wheel Drive Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Kuga	2.5L	I5	CMR(Camera Module Rear)																										
Ford	Kuga	2.5L	I5	D_DCU(Driver Door Control Unit)																										
Ford	Kuga	2.5L	I5	EATC(Electronic Automatic Temperature Control)																										
Ford	Kuga	2.5L	I5	EPS(Electronic Power Steering)																										
Ford	Kuga	2.5L	I5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Kuga	2.5L	I5	GEM(Generic Electronic Module)																										
Ford	Kuga	2.5L	I5	HCM(Headlamp Control Module)																										
Ford	Kuga	2.5L	I5	IC(Instrument Cluster)																										
Ford	Kuga	2.5L	I5	PAM(Parking Aid Module)																										
Ford	Kuga	2.5L	I5	PDM(Passenger's Door Module)																										
Ford	Kuga	2.5L	I5	RCM(Restraint Control Module)																										
Ford	Kuga	2.5L	I5	RETM(Rear Entertainment Module)																										
Ford	Kuga	2.5L	I5	RKE(Remote Keyless Entry)																										
Ford	Kuga	2.5L	I5	SRM(Speech Recognition Module)																										
Ford	Kuga	2.5L	I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)					V		V																			
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)												V	V	V												
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)															V	V	V	V								
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																			V							
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																				V						
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																					V	V	V	V	V	V
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Mondeo	2010 MY	2.5L I5	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.5L I5	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.5L I5	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.5L I5	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.5L I5	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RCM(Restraint Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.5L I5	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.5L I5	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.5L I5	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SYSTEM SEARCH																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)												V	V													
Ford	Mondeo	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	ABS(Anti-Lock Brake System)												V	V													
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	AHCM(Auxiliary Heater Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	BCMii(Body Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CCMii(Cruise Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DDM(Driver's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DSM(Driver's Seat Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HCM(HeadLamp Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PBM(Parking Brake Control Module)																				V	V	V	V	V	V
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RFA(Remote Function Actuator)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TRM(Trailer Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ACM(Audio Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	CDP(Compact Disc Player)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GDM(Generic Display Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	NAV(Navigation System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SRM(Speech Recognition Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	SYSTEM SEARCH																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	GEM(Generic Electronic Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	HCM(Headlamp Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2000 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	2000 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	2000 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1999 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1999 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Mondeo	1998 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1998 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1998 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1997 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1997 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1997 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1997 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	BCM-B(Body Control Module B)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Mustang	3.7L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Mustang	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Mustang	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Mustang	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Mustang	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Mustang	3.7L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.8L	SYSTEM SEARCH																											
Ford	Mustang	3.8L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.8L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.8L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.8L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.8L	RCM(Restraint Control Module)																											
Ford	Mustang	3.9L	SYSTEM SEARCH																											
Ford	Mustang	3.9L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.9L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.9L	GEM(Generic Electronic Module)																											
Ford	Mustang	3.9L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.9L	RCM(Restraint Control Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	BCM-B(Body Control Module B)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.0L	V6 (SOHC)	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.0L	V6 (SOHC)	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Mustang	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Mustang	4.0L	V6 (SOHC)	PAM(Parking Aid Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PSCM(Power Steering Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Mustang	4.0L	V6 (SOHC)	PATS(Passive Anti Theft System)-BETA																										
Ford	Mustang	4.6L	3V	SYSTEM SEARCH																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	BCM-B(Body Control Module B)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	PATS(Passive Anti Theft System)-BETA																										
Ford	Mustang	5.0L	~ 2014	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FDIM(Front Display Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM(Body Control Module)	V																								
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	C-CM(Cruise Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DACM-C(Digital Audio Control Module C)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DDM(Driver's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSM(Driver's Seat Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GWM(Gateway Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	HUD(Head Up Display)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ICM(Information Center Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-A(Movable Roof Control Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-B(Movable Roof Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PAM(Parking Aid Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PDM(Passenger's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Mustang	5.0L	2015 ~	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	RTM(Radio Transceiver Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCM-E(Seat Control Module E)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Mustang	5.4L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	BCM-B(Body Control Module B)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.4L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.4L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.4L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.4L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.4L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.4L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	BCM-B(Body Control Module B)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.8L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.8L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.8L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.8L	4V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	5.8L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.8L	4V	PAM(Parking Aid Module)																										
Ford	Mustang	5.8L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM-B(Body Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ICM(Information Center Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-A(Movable Roof Control Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-B(Movable Roof Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)								V																		
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Diesel(WL-CD)	SYSTEM SEARCH																											
Ford	Ranger	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.0 Diesel(WE-CD)	SYSTEM SEARCH																											
Ford	Ranger	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Ranger	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	PATS(Passive Anti Theft System)																											
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)								V			V															
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Gasoline	SYSTEM SEARCH																											
Ford	Ranger	2.5 Gasoline	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Gasoline	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Gasoline	ACM(Audio Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Ranger	2.5 Gasoline	BCMii(Body Control Module)																											
Ford	Ranger	2.5 Gasoline	DDM(Driver's Door Module)																											
Ford	Ranger	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																											
Ford	Ranger	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Ranger	2.5 Gasoline	IPC(Instrument Panel Control Module)																											
Ford	Ranger	2.5 Gasoline	PAM(Parking Aid Module)																											
Ford	Ranger	2.5 Gasoline	PDM(Passenger's Door Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	SRM(Speech Recognition Module)																											
Ford	Ranger	2.5 Gasoline	TBM(Tracking And Blocking Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TRM(Trailer Module)																											
Ford	Ranger	2.5 Gasoline	PATS(Passive Anti Theft System)-BETA																											
Ford	Ranger	3.0L	Other	SYSTEM SEARCH																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	Other	IC(Instrument Cluster)																										
Ford	Ranger	3.0L	Other	OCSM(Occupant Classification System Module)																										
Ford	Ranger	3.0L	Other	4X4(4x4 Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	3.0L	FFV	SYSTEM SEARCH																										
Ford	Ranger	3.0L	FFV	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	FFV	PATS(Passive Anti Theft System)																										
Ford	Ranger	3.0L	FFV	RAP(Remote Anti-Theft/Personality Module)																										
Ford	Ranger	3.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Ranger	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Ranger	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Ranger	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Ranger	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	4X4(4x4 Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	IC(Instrument Cluster)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	LTM(Liftgate/Trunk Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SECM(Steering Effort Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HUD(Head Up Display)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	BCM(Body Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Taurus	3.5L	TiVCT	2013 ~	GFM(Generic Function Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RACM(Rear Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SCCM(Steering Column Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.0L	2000 ~	SYSTEM SEARCH																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	2000 ~	EATC(Electronic Automatic Temperature Control)																										
Ford	Taurus	3.0L	2000 ~	GEM(Generic Electronic Module)																										
Ford	Taurus	3.0L	2000 ~	IC(Instrument Cluster)																										
Ford	Taurus	3.0L	2000 ~	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	SYSTEM SEARCH																										
Ford	Taurus	3.0L	~ 1999	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	~ 1999	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	~ 1999	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	RIM(Remote Immobilizer Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SYSTEM SEARCH																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PCM(PowerTrain Control Module)			V		V		V																			
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ABS(Anti-Lock Brake System)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ACM(Audio Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	GEM(Generic Electronic Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	IC(Instrument Cluster)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PAM(Parking Aid Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	RCM(Restraint Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SRM(Speech Recognition Module)																										
Ford	Transit	2.0L	2001 ~ 2004	SYSTEM SEARCH																										
Ford	Transit	2.0L	2001 ~ 2004	PCM(PowerTrain Control Module)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.0L	2001 ~ 2004	ASM(Auto Shift Manual)																										
Ford	Transit	2.0L	2001 ~ 2004	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.0L	2001 ~ 2004	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	CSM(Central Security Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2006.5	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2006.5	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	2.4L DIESEL	2006.5	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	PAM(Parking Aid Module)																										
Ford	Transit	2.4L DIESEL	2006.5	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	TBM(Tracking And Blocking Module)																										
Ford	Transit	2.5L DIESEL	SYSTEM SEARCH																											
Ford	Transit	2.5L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	ASM(Auto Shift Manual)																											
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																										
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Transit	2.5L DIESEL	RCM(Restraint Control Module)																											
Ford	Transit	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Transit	2.5L DIESEL	CSM(Central Security Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	RIM(Remote Immobilizer Module)																											
Ford	Transit	2.5L DIESEL	ACM(Audio Control Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Transit	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Transit	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Transit	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Transit	3.7L	TiVCT	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.7L	TiVCT	BCM(Body Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Ford	Transit	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Transit	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.7L	TiVCT	IPM-A(Image Processing Module A)																										
Ford	Transit	3.7L	TiVCT	IPM-B(Image Processing Module B)																										
Ford	Transit	3.7L	TiVCT	PAM(Park Aid Module)																										
Ford	Transit	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Transit	3.7L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.7L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.7L	TiVCT	TRM(Trailer Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V		V		V																			
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Thunderbird	3.9L	4V	SYSTEM SEARCH																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ACM(Audio Control Module)																										
Ford	Thunderbird	3.9L	4V	DDM(Driver's Door Module)																										
Ford	Thunderbird	3.9L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Thunderbird	3.9L	4V	GEM(Generic Electronic Module)																										
Ford	Thunderbird	3.9L	4V	HEC(Hybrid Electrical Cluster)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	REM(Rear Electronic Module)																										
Lincoln	Aviator	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Aviator	4.6L	4V	PCM(Powertrain Control Module)																										
Lincoln	Aviator	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Aviator	4.6L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Aviator	4.6L	4V	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	Aviator	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Aviator	4.6L	4V	IC(Instrument Cluster)																										
Lincoln	Aviator	4.6L	4V	PAM(Parking Aid Module)																										
Lincoln	Aviator	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Aviator	4.6L	4V	TPM(Tire Pressure Monitor)																										
Lincoln	Aviator	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Lincoln	Aviator	4.6L	4V	VSM(Vehicle Security Module)																										
Lincoln	Continental	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Continental	4.6L	4V	PCM(PowerTrain Control Module)																										
Lincoln	Continental	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Continental	4.6L	4V	ACM(Audio Control Module)																										
Lincoln	Continental	4.6L	4V	CPM(Cellular Phone Module)																										
Lincoln	Continental	4.6L	4V	DDM(Driver's Door Module)																										
Lincoln	Continental	4.6L	4V	DSM(Driver's Seat Module)																										
Lincoln	Continental	4.6L	4V	LCM(Lighting Control Module)																										
Lincoln	Continental	4.6L	4V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Continental	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Continental	4.6L	4V	VDM(Vehicle Dynamic Module)																										
Lincoln	Continental	4.6L	4V	VIC(Virtual Image Cluster)																										
Lincoln	Continental	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Continental	4.6L	4V	PATS(Passive Anti Theft System)																										
Lincoln	LS	ALL	SYSTEM SEARCH																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	ABS(Anti-Lock Brake System)																											
Lincoln	LS	ALL	DCSM(Driver-Dual Climate Control Seat Module)																											
Lincoln	LS	ALL	DDM(Driver's Door Module)																											
Lincoln	LS	ALL	DSM(Driver's Seat Module)																											
Lincoln	LS	ALL	EPB(Electronic Parking Brake)																											
Lincoln	LS	ALL	PAM(Parking Aid Module)																											
Lincoln	LS	ALL	RCM(Restraint Control Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	SCLM(Steering Column Locking Module)																											
Lincoln	LS	ALL	EATC(Electronic Automatic Temperature Control)																											
Lincoln	LS	ALL	GEM(Generic Electronic Module)																											
Lincoln	LS	ALL	HEC(Hybrid Electrical Cluster)																											
Lincoln	LS	ALL	PCSM(Passenger Climate Control Seat Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	MKS	3.7L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKS	3.7L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.7L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2009	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2009	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2009	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2010 ~	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2010 ~	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	MKS	3.7L	4V	2010 ~	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2010 ~	HUD(Head Up Display)																									
Lincoln	MKS	3.7L	4V	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2010 ~	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKX	3.5L	4V	2007	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2007	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2007	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2007	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2007	EATC(Electronic Automatic Temperature Control)																									
Lincoln	MKX	3.5L	4V	2007	GEM(Generic Electronic Module)																									
Lincoln	MKX	3.5L	4V	2007	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2007	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2007	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2007	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2007	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2007	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2007	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2007	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2007	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2008	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2008	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2008	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2008	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2008	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2008	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	MKX	3.5L	4V	2008	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2008	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2008	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2008	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2008	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2008	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2008	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2008	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2008	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2009	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2009	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2009	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2009	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2009	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2010	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2010	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2010	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	MKX	3.5L	4V	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2010	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2010	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2010	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2010	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2010	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2010	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2010	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKZ	3.0L	2006	SYSTEM SEARCH																										
Lincoln	MKZ	3.0L	2006	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.0L	2006	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.0L	2006	ACM(Audio Control Module)																										
Lincoln	MKZ	3.0L	2006	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.0L	2006	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.0L	2006	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.0L	2006	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.0L	2006	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.0L	2006	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.0L	2006	IC(Instrument Cluster)																										
Lincoln	MKZ	3.0L	2006	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.0L	2006	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.0L	2006	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2007	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2007	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2007	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2007	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2007	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2007	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2007	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	MKZ	3.5L	2007	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2007	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.5L	2007	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.5L	2007	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2007	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2007	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2007	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2007	PATS(Passive Anti Theft System)																										
Lincoln	MKZ	3.5L	2008	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2008	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2008	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2008	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2008	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2008	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2008	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2008	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2008	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2008	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2008	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2008	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2008	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2008	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2008	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2008	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2009	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2009	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2009	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2009	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2009	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2009	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2009	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2009	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2009	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	MKZ	3.5L	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2009	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2009	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2009	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2009	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2009	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2009	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2009	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2010	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2010	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2010	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2010	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2010	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2010	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2010	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2010	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2010	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	3.5L	2010	FDIM(Front Display Interface Module)																										
Lincoln	MKZ	3.5L	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2010	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	3.5L	2010	HCM(Headlamp Control Module)																										
Lincoln	MKZ	3.5L	2010	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2010	ILCM(Interior Lighting Control Module)																										
Lincoln	MKZ	3.5L	2010	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	3.5L	2010	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2010	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2010	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2010	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	3.5L	2010	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	3.5L	2010	TCM(Transmission Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)		V																								
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRCM(Transmission Range Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM(Body Control Module)		V																								
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM(Transmission Range Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Lincoln	Navigator	2007 ~	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	APIM(Accessory Protocol Interface Module)																										
Lincoln	Navigator	2007 ~	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GPSM(Global Positioning System Module)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	2007 ~	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	2007 ~	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	2007 ~	5.4L	PRB(Power Running Board)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCU(Audio Rear Control Unit)																										
Lincoln	Navigator	2007 ~	5.4L	RETM(Rear Entertainment Module)																										
Lincoln	Navigator	2007 ~	5.4L	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	Navigator	2007 ~	5.4L	TCCM(Transfer Case Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	TCM(Transmission Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	2007 ~	5.4L	4X4(4x4 Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PATS(Passive Anti Theft System)																										
Lincoln	Navigator	~ 2007	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	GEM(Generic Electronic Module)																										
Lincoln	Navigator	~ 2007	5.4L	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Navigator	~ 2007	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	~ 2007	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	~ 2007	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	~ 2007	5.4L	RIM(Remote Immobilizer Module)																										
Lincoln	Navigator	~ 2007	5.4L	VSM(Vehicle Security Module)																										
Lincoln	Town Car	4.6L	2V	SYSTEM SEARCH																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	LCM(Lighting Control Module)																										
Lincoln	Town Car	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Lincoln	Town Car	4.6L	2V	DDM(Driver's Door Module)																										
Lincoln	Town Car	4.6L	2V	DSM(Driver's Seat Module)																										
Lincoln	Town Car	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Town Car	4.6L	2V	RATC(Rear Air Temperature Control)																										
Lincoln	Town Car	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Lincoln	Town Car	4.6L	2V	PAM(Parking Aid Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	HEC(Hybrid Electrical Cluster)																										
Lincoln	Town Car	4.6L	2V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Town Car	4.6L	2V	RASM(Rear Air Suspension Module)																										
Mercury	Grand Marquis	4.6L	2V	SYSTEM SEARCH																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	DDM(Driver's Door Module)																										
Mercury	Grand Marquis	4.6L	2V	IC(Instrument Cluster)																										
Mercury	Grand Marquis	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Grand Marquis	4.6L	2V	LCM(Lighting Control Module)																										
Mercury	Grand Marquis	4.6L	2V	MC(Message Center)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RIM(Remote Immobilizer Module)																										
Mercury	Grand Marquis	4.6L	2V	GEM(Generic Electronic Module)																										
Mercury	Grand Marquis	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Mercury	Marauder	4.6L	4V	SYSTEM SEARCH																										
Mercury	Marauder	4.6L	4V	PCM(Powertrain Control Module)																										
Mercury	Marauder	4.6L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Marauder	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Marauder	4.6L	4V	RASM(Rear Air Suspension Module)																										
Mercury	Marauder	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Mercury	Marauder	4.6L	4V	DDM(Driver's Door Module)																										
Mercury	Marauder	4.6L	4V	LCM(Lighting Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	Milan	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SYSTEM SEARCH																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Milan	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	Milan	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Milan	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	Milan	3.0L	4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Milan	3.0L	4V	PATS(Passive Anti Theft System)																										
Mercury	Montego	3.0L	4V	SYSTEM SEARCH																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Montego	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Montego	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Montego	3.0L	4V	DSM(Driver's Seat Module)																										
Mercury	Montego	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Montego	3.0L	4V	GEM(Generic Electronic Module)																										
Mercury	Montego	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Montego	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Montego	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Montego	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Mercury	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Mercury	Mountaineer	2010 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2010 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2010 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2010 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2010 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2010 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.6L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	Mountaineer	2009 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2009 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2009 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2009 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2009 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2008 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2008 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2008 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2008 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	Mountaineer	2007 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2007 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2007 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2007 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2007 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2006 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2006 MY	4.6L	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	Mountaineer	2006 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2006 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2006 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2006 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2006 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2003 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2003 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2003 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2003 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2003 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2003 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2003 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2002 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2002 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2002 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2002 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	Mountaineer	2002 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2002 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2001 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2001 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2001 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2001 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2001 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2001 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2000 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2000 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2000 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2000 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2000 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2000 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	1999 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1999 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1999 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1999 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1999 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1999 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	1998 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1998 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1998 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1998 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1998 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1997 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1997 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1997 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1997 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1997 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	RVC Configuration	Reset KAM(Keep Alive Memory)	Reset the DPF Learned Values	Reset Differential Pressure Sensor Learned Values	Reset the Water in Fuel Warning Indicator	Reset the Knock Sensor Learned Values	Reset the High Pressure Fuel System Learned Values	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values	Powertrain Control Module Central Car Configuration Update	Fuel System Vaporizer Prime	Configuration the yaw rate sensor	Pressure Sensor Calibration	Read the Sensor Cluster serial Number	CAR Mod(Normal)	CAR Mod(Transpot)	TPMS Sensor Learn Routine	BCMii Crash Reset	Driver's Seat Module	Head Lamp Alignment	EPB Parameter Reset/Configuration	Assembly Check	Inclination Sensor Calibration	Maintenance Mode	Static Apply	Clear Stored Clutch Engagement Point
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Vehicle Info.	Vehicle Info.	Vehicle Info.																												
Ford	Crown Victoria	4.6L	2V	SYSTEM SEARCH																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	Crown Victoria	4.6L	2V	DDM(Driver's Door Module)																										
Ford	Crown Victoria	4.6L	2V	IC(Instrument Cluster)																										
Ford	Crown Victoria	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Crown Victoria	4.6L	2V	LCM(Lighting Control Module)																										
Ford	Crown Victoria	4.6L	2V	MC(Message Center)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																										
Ford	Crown Victoria	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	Crown Victoria	4.6L	2V	GEM(Generic Electronic Module)																										
Ford	Crown Victoria	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.4L	DIESEL	SYSTEM SEARCH																										
Ford	Ecosport	1.4L	DIESEL	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.4L	DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.4L	DIESEL	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.4L	DIESEL	IC(Instrument Cluster)																										
Ford	Ecosport	1.4L	DIESEL	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	1.6L	FFV	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Ecosport	1.6L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	1.6L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	1.6L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	1.6L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	1.6L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	ZETEC ROCAM	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	SYSTEM SEARCH																										
Ford	Ecosport	2.0L	FFV	PCM(PowerTrain Control Module)																										
Ford	Ecosport	2.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ecosport	2.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ecosport	2.0L	FFV	IC(Instrument Cluster)																										
Ford	Ecosport	2.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ecosport	2.0L	FFV	TBM(Tracking And Blocking Module)																										
Ford	Escort	2.0L	SYSTEM SEARCH																											
Ford	Escort	2.0L	PCM(PowerTrain Control Module)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Escort	2.0L	ECS(Electronic Crash Sensor)																											
Ford	Escort	2.0L	PATS(Passive Anti Theft System)																											
Ford	Escort	2.0L	RAP(Remote Anti-Theft/Personality Module)																											
Ford	Edge	3.5L	4V	SYSTEM SEARCH																										
Ford	Edge	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Edge	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																										
Ford	Edge	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Edge	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Edge	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	4V	IC(Instrument Cluster)																										
Ford	Edge	3.5L	4V	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Edge	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Edge	3.5L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Edge	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.5L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.5L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.5L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.5L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.5L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.5L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.5L	TiVCT	RFA(Remote Function Actuator)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Edge	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.5L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.5L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.5L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Edge	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Edge	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Edge	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Edge	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Edge	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Edge	3.7L	TiVCT	BCM(Body Control Module)																										
Ford	Edge	3.7L	TiVCT	C-CM(Cruise Control Module)																										
Ford	Edge	3.7L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Edge	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Edge	3.7L	TiVCT	FLM(Front Lighting Control Module)																										
Ford	Edge	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Edge	3.7L	TiVCT	HUD(Head Up Display)																										
Ford	Edge	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Edge	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Edge	3.7L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Edge	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Edge	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Edge	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Edge	3.7L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Edge	3.7L	TiVCT	RLCM-A(Rear Lighting Control Module A)																										
Ford	Edge	3.7L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	Edge	3.7L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	Edge	3.7L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Edge	3.7L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Edge	3.7L	TiVCT	TBM(Tracking And Blocking Module)																										
Ford	Edge	3.7L	TiVCT	PATS(Passive Anti Theft System)																										
Ford	Escape	Up to 2004	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Escape	Up to 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	Up to 2004	Immobilizer																											
Ford	Escape	Up to 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	Up to 2004	RCM(Restraint Control Module)																											
Ford	Escape	Up to 2004	GEM(Generic Electronic Module)																											
Ford	Escape	From 2004	SYSTEM SEARCH																											
Ford	Escape	From 2004	PCM(PowerTrain Control Module)																											
Ford	Escape	From 2004	PATS(Passive Anti Theft System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																											
Ford	Escape	From 2004	RCM(Restraint Control Module)																											
Ford	Escape	From 2004	IC(Instrument cluster)																											
Ford	Escape	From 2004	GEM(Generic Electronic Module)																											
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Excursion	GASOLINE	SYSTEM SEARCH																											
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																											
Ford	Excursion	GASOLINE	ABS(Anti-Lock Brake System)																											
Ford	Excursion	GASOLINE	CSM(Central Security Module)																											
Ford	Excursion	GASOLINE	DSM(Driver's Seat Module)																											
Ford	Excursion	GASOLINE	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	GASOLINE	ECS(Electronic Crash Sensor)																											
Ford	Excursion	GASOLINE	GEM(Generic Electronic Module)																											
Ford	Excursion	GASOLINE	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	GASOLINE	OTC(Overhead Trip Computer)																											
Ford	Excursion	GASOLINE	PAM(Parking Aid Module)																											
Ford	Excursion	GASOLINE	PATS(Passive Anti Theft System)																											
Ford	Excursion	GASOLINE	TCM(Transmission Control Module)																											
Ford	Excursion	GASOLINE	VSM(Vehicle Security Module)																											
Ford	Excursion	DIESEL	SYSTEM SEARCH																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																											
Ford	Excursion	DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Excursion	DIESEL	CSM(Central Security Module)																											
Ford	Excursion	DIESEL	DSM(Driver's Seat Module)																											
Ford	Excursion	DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Excursion	DIESEL	ECS(Electronic Crash Sensor)																											
Ford	Excursion	DIESEL	GEM(Generic Electronic Module)																											
Ford	Excursion	DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Excursion	DIESEL	OTC(Overhead Trip Computer)																											
Ford	Excursion	DIESEL	PAM(Parking Aid Module)																											
Ford	Excursion	DIESEL	PATS(Passive Anti Theft System)																											
Ford	Excursion	DIESEL	TCM(Transmission Control Module)																											
Ford	Excursion	DIESEL	VSM(Vehicle Security Module)																											
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	EATC(Electronic Automatic Temperature Control)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VSM(Vehicle Security Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TBC(Trailer Brake Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCCM(Transfer Case Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PATS(Passive Anti Theft System)																									
Ford	ExpeditionExpedition EL	5.4L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	GEM(Generic Electronic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	5.4L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	5.4L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	5.4L	2V	VSM(Vehicle Security Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SYSTEM SEARCH																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	APIM(Accessory Protocol Interface Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSM(Driver's Seat Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	ExpeditionExpedition EL	4.6L	2V	GPSM(Global Positioning System Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Ford	ExpeditionExpedition EL	4.6L	2V	IC(Instrument Cluster)																										
Ford	ExpeditionExpedition EL	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PRB(Power Running Board)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RCU(Audio Rear Control Unit)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RETM(Rear Entertainment Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	ExpeditionExpedition EL	4.6L	2V	TCM(Transmission Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	4X4(4x4 Control Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	RIM(Remote Immobilizer Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Ford	ExpeditionExpedition EL	4.6L	2V	VSM(Vehicle Security Module)																										
Ford	Explorer	2015 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2015 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2014 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2014 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2013 MY	3.5L	TiVCT	PATS(Passive Anti Theft System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2012 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2012 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2011 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Explorer	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2010 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer	2009 MY	4.6L	3V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer	2005 MY	SYSTEM SEARCH																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2005 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2005 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2005 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2005 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2005 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2005 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2004 MY	SYSTEM SEARCH																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2004 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2004 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2004 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2004 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2004 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2004 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2003 MY	SYSTEM SEARCH																											
Ford	Explorer	2003 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2003 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2003 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2003 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2003 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2003 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2003 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2002 MY	SYSTEM SEARCH																											
Ford	Explorer	2002 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2002 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2002 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2002 MY	4X4(4x4 Control Module)																											
Ford	Explorer	2002 MY	HEC(Hybrid Electrical Cluster)																											
Ford	Explorer	2002 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2002 MY	VSM(Vehicle Security Module)																											
Ford	Explorer	2001 MY	SYSTEM SEARCH																											
Ford	Explorer	2001 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2001 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2001 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2001 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer	2001 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2001 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	SYSTEM SEARCH																											
Ford	Explorer	2000 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	2000 MY	RCM(Restraint Control Module)																											
Ford	Explorer	2000 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	2000 MY	GEM(Generic Electronic Module)																											
Ford	Explorer	2000 MY	PAM(Parking Aid Module)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																											
Ford	Explorer	1999 MY	SYSTEM SEARCH																											
Ford	Explorer	1999 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1999 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1999 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1999 MY	PAM(Parking Aid Module)																											
Ford	Explorer	1998 MY	SYSTEM SEARCH																											
Ford	Explorer	1998 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1998 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1998 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1998 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer	1997 MY	SYSTEM SEARCH																											
Ford	Explorer	1997 MY	PCM(PowerTrain Control Module)																											
Ford	Explorer	1997 MY	ABS(Anti-Lock Brake System)																											
Ford	Explorer	1997 MY	RCM(Restraint Control Module)																											
Ford	Explorer	1997 MY	RIM(Remote Immobilizer Module)																											
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer SportTrac	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer SportTrac	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer SportTrac	2008 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SYSTEM SEARCH																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	TCM(Transmission Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	4X4(4x4 Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ACM(Audio Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	IC(Instrument Cluster)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PAM(Parking Aid Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PRB(Power Running Board)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																									
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2004 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																									
Ford	E-Series	5.4L	2V	2004 ~	RAP(Remote Anti-Theft/Personality Module)																									
Ford	E-Series	5.4L	2V	2004 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2004 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2004 ~	VSM(Vehicle Security Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SYSTEM SEARCH																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	E-Series	5.4L	2V	2009 ~	ACM(Audio Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	E-Series	5.4L	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	E-Series	5.4L	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	E-Series	5.4L	2V	2009 ~	IPC(Instrument Panel Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	E-Series	5.4L	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	SDARS(Satellite Digital Audio Receiver System)																									
Ford	E-Series	5.4L	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	E-Series	5.4L	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																										
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																										
Ford	F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																										
Ford	F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																									
Ford	F150	4.6L(BETA)	3V	SYSTEM SEARCH																										
Ford	F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																										
Ford	F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																										
Ford	F150	4.6L(BETA)	3V	ACM(Audio Control Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																										
Ford	F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																										
Ford	F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																										
Ford	F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																										
Ford	F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	4.6L(BETA)	3V	IC(Instrument Cluster)																										
Ford	F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																										
Ford	F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																										
Ford	F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																										
Ford	F150	4.6L(BETA)	3V	PRB(Power Running Board)																										
Ford	F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																										
Ford	F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																										
Ford	F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																										
Ford	F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																										
Ford	F150	5.0L	TiVCT	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	F150	5.0L	TiVCT	PCM(Powertrain Control Module)																										
Ford	F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	F150	5.0L	TiVCT	ACM(Audio Control Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	F150	5.0L	TiVCT	DSM(Driver's Seat Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	5.0L	TiVCT	IC(Instrument Cluster)																										
Ford	F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																										
Ford	F150	5.0L	TiVCT	PRB(Power Running Board)																										
Ford	F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	F150	5.0L	TiVCT	RCM(Restraint Control Module)																										
Ford	F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																										
Ford	F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																										
Ford	F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																										
Ford	F150	5.0L	TiVCT	TCM(Transmission Control Module)																										
Ford	F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																										
Ford	F150	5.4L	3V	2009 ~	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																									
Ford	F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatlation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																									
Ford	F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																									
Ford	F150	5.4L	3V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																									
Ford	F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																									
Ford	F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																									
Ford	F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2009 ~	PRB(Power Running Board)																									
Ford	F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																									
Ford	F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																									
Ford	F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F150	6.2L(BETA)	2V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																										
Ford	F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																										
Ford	F150	6.2L(BETA)	2V	ACM(Audio Control Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																										
Ford	F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																										
Ford	F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																										
Ford	F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																										
Ford	F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																										
Ford	F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																										
Ford	F150	6.2L(BETA)	2V	IC(Instrument Cluster)																										
Ford	F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																										
Ford	F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																										
Ford	F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																										
Ford	F150	6.2L(BETA)	2V	PRB(Power Running Board)																										
Ford	F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																										
Ford	F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																										
Ford	F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																										
Ford	F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																										
Ford	F150	Other	2004 ~ 2008	SYSTEM SEARCH																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																										
Ford	F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																										
Ford	F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																										
Ford	F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																										
Ford	F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F150	Other	2004 ~ 2008	IC(Instrument Cluster)																										
Ford	F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																										
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																										
Ford	F250	7.3L	SYSTEM SEARCH																											
Ford	F250	7.3L	PCM(PowerTrain Control Module)																											
Ford	F250	7.3L	ABS(Anti-Lock Brake System)																											
Ford	F250	7.3L	ECS(Electronic Crash Sensor)																											
Ford	F250	7.3L	GEM(Generic Electronic Module)																											
Ford	F250	6.2L	SYSTEM SEARCH																											
Ford	F250	6.2L	PCM(Powertrain Control Module)																											
Ford	F250	6.2L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.2L	ACM(Audio Control Module)																											
Ford	F250	6.2L	APIM(Accessory Protocol Control Module)																											
Ford	F250	6.2L	BCMii(Body Control Module)																											
Ford	F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																											
Ford	F250	6.2L	DSM(Driver Seat Module)																											
Ford	F250	6.2L	GPSM(Global Positioning System Module)																											
Ford	F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																											
Ford	F250	6.2L	IPC(Instrument Panel Control Module)																											
Ford	F250	6.2L	PAM(Parking Aid Module)																											
Ford	F250	6.2L	RCM(Restraint Control Module)																											
Ford	F250	6.2L	SCCM(Streering Colume Control Module)																											
Ford	F250	6.2L	TBC(Trailer Brake Control Module)																											
Ford	F250	6.2L	TCCM(Transfer Case Control Module)																											
Ford	F250	6.2L	TPM(Tire Pressure Monitor)																											
Ford	F250	6.0L	SYSTEM SEARCH																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	PCM(PowerTrain Control Module)																											
Ford	F250	6.0L	ABS(Anti-Lock Brake System)																											
Ford	F250	6.0L	GEM(Generic Electronic Module)																											
Ford	F250	6.0L	HEC(Hybrid Electrical Cluster)																											
Ford	F250	6.0L	OTC(Overhead Trip Computer)																											
Ford	F250	6.0L	PAM(Parking Aid Module)																											
Ford	F250	6.0L	PATS(Passive Anti Theft System)																											
Ford	F250	6.0L	RCM(Restraint Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	TCM(Transmission Control Module)																											
Ford	F250	6.0L	VSM(Vehicle Security Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SYSTEM SEARCH																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM(PowerTrain Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4(4x4 Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS(Anti-Lock Brake System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM(Audio Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM(Auxiliary Heater Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM(Accessory Protocol Interface Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM(Circuit Deactivation Ignition Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM(Driver's Seat Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GPSM(Global Positioning System Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC(Instrument Cluster)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM(Parking Aid Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM(Restraint Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM(Rear Entertainment Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS(Satellite Digital Audio Receiver System)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC(Trailer Brake Control Module)																										
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM(Transmission Control Module)																										
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																									
Ford	Fiesta	1.4L	DURATEC 16V	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	DURATEC 16V	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	DURATEC 16V	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																										
Ford	Fiesta	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	DURATEC	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fiesta	1.6L	DURATEC	BCMii(Body Control Module)																										
Ford	Fiesta	1.6L	DURATEC	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	TiVCT	TCM(Transmission Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																										
Ford	Fiesta	1.6L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	BCM(Body Control Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fiesta	1.6L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Fiesta	1.6L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Fiesta	1.6L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	TiVCT	RFA(Remote Function Actuator)																										
Ford	Fiesta	1.6L	TiVCT	VSM(Vehicle Security Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	SYSTEM SEARCH																										
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.6L	Zetec Rocam	IC(Instrument Cluster)																										
Ford	Fiesta	1.6L	Zetec Rocam	RCM(Restraint Control Module)																										
Ford	Fiesta	1.6L	Zetec Rocam	RKE(Remote Keyless Entry)																										
Ford	Fiesta	1.6L	Zetec Rocam	TCM(Transmission Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	SYSTEM SEARCH																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																										
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																										
Ford	Fiesta	2.0L	SYSTEM SEARCH																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																											
Ford	Fiesta	2.0L	ACM(Audio Control Module)																											
Ford	Fiesta	2.0L	EATC(Electronic Automatic Temperature Control)																											
Ford	Fiesta	2.0L	GEM(Generic Electronic Module)																											
Ford	Fiesta	2.0L	IC(Instrument Cluster)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																											
Ford	Fiesta	2.0L	RCM(Restraint Control Module)																											
Ford	Fiesta	2.0L	PATS(Passive Anti Theft System)-BETA																											
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	SYSTEM SEARCH																										
Ford	Focus	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	ZETEC ROCAM	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Focus	1.6L	ZETEC ROCAM	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	DURATEC-HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	1.6L	DURATEC-HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.6L	DURATEC-HE/I4	MC(Message Center)																										
Ford	Focus	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Focus	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic power steering)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SYSTEM SEARCH																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus	1.8L	DURATEC HE/I4	ACM(Audio control module)																										
Ford	Focus	1.8L	DURATEC HE/I4	CDP(Compact Disc Player)																										
Ford	Focus	1.8L	DURATEC HE/I4	CSM(Central Security Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus	1.8L	DURATEC HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	1.8L	DURATEC HE/I4	EPS(Electronic power steering)																										
Ford	Focus	1.8L	DURATEC HE/I4	GDM(Generic Display Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	IC(Instrument cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	NAV(Navigation System)																										
Ford	Focus	1.8L	DURATEC HE/I4	PAM(Parking Aid Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus	1.8L	DURATEC HE/I4	SRM(Speech recognition module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	1.8L	DURATEC HE/I4	MC(Message Center)																										
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																										
Ford	Focus	1.8L	DURATEC HE/I4	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	FDIM(Front Display Interface Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L DURATEC HE/I4	2008~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SYSTEM SEARCH																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TCM(Transmission control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CSM(Central Security Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EPS(Electronic power steering)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GDM(Generic Display Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HEC(Hybrid Electrical Cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	IC(Instrument cluster)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	NAV(Navigation System)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RKE(Remote Keyless Entry)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TBM(Tracking And Blocking Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SRM(Speech recognition module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SYSTEM SEARCH																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ACM(Audio Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	APIM(Accessory Protocol Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	BCM(Body Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DDM(Driver's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	GPSM(Global Positioning System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	IPC(Instrument Panel Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	OCSM(Occupant Classification System Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PAM(Parking Aid Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PSCM(Power Steering Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RCM(Restraint Control Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SASM(Steering Angle Sensor Module)																										
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	TCM(Transmission Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CDP(Compact Disc Player)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Focus	2.0L DIESEL	2003 ~ 2008	D_DCU(Driver Door Control Unit)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FACM(Fuel Additive Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	HCM(Headlamp Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PAM(Parking Aid Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RETM(Rear Entertainment Module)																										
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RKE(Remote Keyless Entry)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	SYSTEM SEARCH																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	IC(Instrument cluster)																										
Ford	Focus	2.3L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	SYSTEM SEARCH																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PCM(PowerTrain Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	TCM(Transmission control module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ABS(Anti-Lock Brake System)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	EPS(Electronic power steering)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	RCM(Restraint Control Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	GEM(Generic Electronic Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	IC(Instrument cluster)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	DDM(Driver's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PDM(Passenger's Door Module)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	MC(Message Center)																										
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ACM(Audio control module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatlation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	BCMii(Body Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	DDM(Driver's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Focus C-MAX	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Focus C-MAX	1.6L	DURATEC VCT	TRM(Trailer Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CDP(Compact Disc Player)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CMR(Camera Module Rear)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPS(Electronic Power Steering)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GDM(Generic Display Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	HCM(Headlamp Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	NAV(Navigation System)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																										
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Flex	3.5L	4V	SYSTEM SEARCH																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	4V	ACM(Audio control module)																										
Ford	Flex	3.5L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	4V	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	4V	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	4V	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	4V	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	4V	IC(Instrument cluster)																										
Ford	Flex	3.5L	4V	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	4V	LTM(Liftgate/Trunk Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Flex	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	4V	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	4V	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	4V	Factory Keyless Entry Code																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio control module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC(Instrument cluster)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Flex	3.5L	TiVCT	SYSTEM SEARCH																										
Ford	Flex	3.5L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Flex	3.5L	TiVCT	4X4(4x4 Control Module)																										
Ford	Flex	3.5L	TiVCT	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Flex	3.5L	TiVCT	ACM(Audio control module)																										
Ford	Flex	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Flex	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Flex	3.5L	TiVCT	DDM(Driver's Door Module)																										
Ford	Flex	3.5L	TiVCT	DSM(Driver's Seat Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																										
Ford	Flex	3.5L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Flex	3.5L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Flex	3.5L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Flex	3.5L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Flex	3.5L	TiVCT	HCM(Headlamp Control Module)																										
Ford	Flex	3.5L	TiVCT	HCM-2(Headlamp Control Module2)																										
Ford	Flex	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Flex	3.5L	TiVCT	IC(Instrument cluster)																										
Ford	Flex	3.5L	TiVCT	ILCM(Interior Lighting Control Module)																										
Ford	Flex	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																										
Ford	Flex	3.5L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Flex	3.5L	TiVCT	PAM(Parking Aid Module)																										
Ford	Flex	3.5L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Flex	3.5L	TiVCT	RCM(Restraint Control Module)																										
Ford	Flex	3.5L	TiVCT	RETM(Rear Entertainment Module)																										
Ford	Flex	3.5L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Ford	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Ford	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Ford	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Ford	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Ford	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Ford	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Ford	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Ford	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											
Ford	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Ford	Freestyle	3.0L	4V	SYSTEM SEARCH																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Freestyle	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Freestyle	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Freestyle	3.0L	4V	ACM(Audio Control Module)																										
Ford	Freestyle	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Freestyle	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Freestyle	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Freestyle	3.0L	4V	IC(Instrument Cluster)																										
Ford	Freestyle	3.0L	4V	PAM(Parking Aid Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Freestyle	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Freestyle	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Five Hundred	3.0L	4V	SYSTEM SEARCH																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Five Hundred	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Five Hundred	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Five Hundred	3.0L	4V	ACM(Audio Control Module)																										
Ford	Five Hundred	3.0L	4V	DSM(Driver's Seat Module)																										
Ford	Five Hundred	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Five Hundred	3.0L	4V	GEM(Generic Electronic Module)																										
Ford	Five Hundred	3.0L	4V	IC(Instrument Cluster)																										
Ford	Five Hundred	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Five Hundred	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Five Hundred	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Ford GT	5.4L	4V	SYSTEM SEARCH																										
Ford	Ford GT	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																										
Ford	Ford GT	5.4L	4V	IC(Instrument Cluster)																										
Ford	Ford GT	5.4L	4V	PATS(Passive Anti Theft System)																										
Ford	Ford GT	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	DURATEC	SYSTEM SEARCH																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	DURATEC	TCM(Transmission control module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Fusion	1.6L	DURATEC	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	DURATEC	IC(Instrument cluster)																										
Ford	Fusion	1.6L	DURATEC	ACM(Audio control module)																										
Ford	Fusion	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																										
Ford	Fusion	1.6L	DURATEC	GEM(Generic Electronic Module)																										
Ford	Fusion	1.6L	DURATEC	SRM(Speech Recognition Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SYSTEM SEARCH																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BCM(Body Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HUD(Head Up Display)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM(Secondary OBD Control Module A)																										
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	TCU(Telematic Control Unit Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Fusion	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Ford	Fusion	2.5L	IVCT	SYSTEM SEARCH																										
Ford	Fusion	2.5L	IVCT	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	IVCT	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	IVCT	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	IVCT	BCM(Body Control Module)																										
Ford	Fusion	2.5L	IVCT	C-CM(Cruise Control Module)																										
Ford	Fusion	2.5L	IVCT	DACM-C(Digital Audio Control Module C)																										
Ford	Fusion	2.5L	IVCT	DDM(Driver's Door Module)																										
Ford	Fusion	2.5L	IVCT	DSM(Driver's Seat Module)																										
Ford	Fusion	2.5L	IVCT	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	IVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Fusion	2.5L	IVCT	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	IVCT	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	IVCT	GWM(Gateway Module A)																										
Ford	Fusion	2.5L	IVCT	HUD(Head Up Display)																										
Ford	Fusion	2.5L	IVCT	IPC(Instrument Panel Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatlation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Fusion	2.5L	IVCT	IPM-A(Image Processing Module A)																										
Ford	Fusion	2.5L	IVCT	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	IVCT	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	IVCT	PDM(Passenger's Door Module)																										
Ford	Fusion	2.5L	IVCT	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	IVCT	RACM(Rear Audio Control Module)																										
Ford	Fusion	2.5L	IVCT	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	IVCT	RTM(Radio Transceiver Module)																										
Ford	Fusion	2.5L	IVCT	SCCM(Steering Column Control Module)																										
Ford	Fusion	2.5L	IVCT	SCM-E(Seat Control Module E)																										
Ford	Fusion	2.5L	IVCT	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	IVCT	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.0L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.0L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.0L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.0L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.0L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.0L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.0L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.0L	4V	TBM(Tracking And Blocking Module)																										
Ford	Fusion	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Fusion	3.0L	4V	PATS(Passive Anti Theft System)																										
Ford	Fusion	3.5L	4V	SYSTEM SEARCH																										
Ford	Fusion	3.5L	4V	PCM(PowerTrain Control Module)																										
Ford	Fusion	3.5L	4V	TCM(Transmission Control Module)																										
Ford	Fusion	3.5L	4V	4X4(4x4 Control Module)																										
Ford	Fusion	3.5L	4V	ABS(Anti-Lock Brake System)																										
Ford	Fusion	3.5L	4V	ACM(Audio Control Module)																										
Ford	Fusion	3.5L	4V	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																										
Ford	Fusion	3.5L	4V	FDIM(Front Display Interface Module)																										
Ford	Fusion	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Fusion	3.5L	4V	GPSM(Global Positioning System Module)																										
Ford	Fusion	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Fusion	3.5L	4V	IPC(Instrument Panel Control Module)																										
Ford	Fusion	3.5L	4V	OCSM(Occupant Classification System Module)																										
Ford	Fusion	3.5L	4V	PAM(Parking Aid Module)																										
Ford	Fusion	3.5L	4V	PSCM(Power Steering Control Module)																										
Ford	Fusion	3.5L	4V	RCM(Restraint Control Module)																										
Ford	Fusion	3.5L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Fusion	3.5L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Fusion	3.5L	4V	TBM(Tracking And Blocking Module)																										
Ford	KA	2000 MY	SYSTEM SEARCH																											
Ford	KA	2000 MY	PCM(PowerTrain Control Module)																											
Ford	KA	2000 MY	ABS(Anti-Lock Brake System)																											
Ford	KA	2000 MY	RCM(Restraint Control Module)																											
Ford	KA	1999 MY	PCM(PowerTrain Control Module)																											
Ford	KA	1999 MY	ABS(Anti-Lock Brake System)																											
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Kuga	2.0L DIESEL	SYSTEM SEARCH																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Kuga	2.0L DIESEL	TCM(Transmission Control Module)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																											
Ford	Kuga	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																											
Ford	Kuga	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																											
Ford	Kuga	2.0L DIESEL	AWD(All Wheel Drive Module)																											
Ford	Kuga	2.0L DIESEL	BCMii(Body Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Kuga	2.0L DIESEL	CCMii(Cruise Control Module)																											
Ford	Kuga	2.0L DIESEL	CMR(Camera Module Rear)																											
Ford	Kuga	2.0L DIESEL	D_DCU(Driver Door Control Unit)																											
Ford	Kuga	2.0L DIESEL	DDM(Driver's Door Module)																											
Ford	Kuga	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																											
Ford	Kuga	2.0L DIESEL	EPS(Electronic Power Steering)																											
Ford	Kuga	2.0L DIESEL	FDSM(Front Distance Sensing Module)																											
Ford	Kuga	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																											
Ford	Kuga	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																											
Ford	Kuga	2.0L DIESEL	GEM(Generic Electronic Module)																											
Ford	Kuga	2.0L DIESEL	GPSM(Global Positioning System Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																											
Ford	Kuga	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Kuga	2.0L DIESEL	IPM-A(Image Processing Module A)																											
Ford	Kuga	2.0L DIESEL	IPM-B(Image Processing Module B)																											
Ford	Kuga	2.0L DIESEL	IPC(Instrument Panel Control Module)																											
Ford	Kuga	2.0L DIESEL	IC(Instrument Cluster)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																											
Ford	Kuga	2.0L DIESEL	PSCM(Power Steering Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																											
Ford	Kuga	2.0L DIESEL	RFA(Remote Function Actuator)																											
Ford	Kuga	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																											
Ford	Kuga	2.0L DIESEL	RETM(Rear Entertainment Module)																											
Ford	Kuga	2.0L DIESEL	SASM(Steering Angle Sensor Module)																											
Ford	Kuga	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																											
Ford	Kuga	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																											
Ford	Kuga	2.0L DIESEL	SRM(Speech Recognition Module)																											
Ford	Kuga	2.0L DIESEL	TRM(Trailer Module)																											
Ford	Kuga	2.5L	I5	SYSTEM SEARCH																										
Ford	Kuga	2.5L	I5	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.5L	I5	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.5L	I5	ACM(Audio Control Module)																										
Ford	Kuga	2.5L	I5	AWD(All Wheel Drive Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Kuga	2.5L	I5	CMR(Camera Module Rear)																										
Ford	Kuga	2.5L	I5	D_DCU(Driver Door Control Unit)																										
Ford	Kuga	2.5L	I5	EATC(Electronic Automatic Temperature Control)																										
Ford	Kuga	2.5L	I5	EPS(Electronic Power Steering)																										
Ford	Kuga	2.5L	I5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Kuga	2.5L	I5	GEM(Generic Electronic Module)																										
Ford	Kuga	2.5L	I5	HCM(Headlamp Control Module)																										
Ford	Kuga	2.5L	I5	IC(Instrument Cluster)																										
Ford	Kuga	2.5L	I5	PAM(Parking Aid Module)																										
Ford	Kuga	2.5L	I5	PDM(Passenger's Door Module)																										
Ford	Kuga	2.5L	I5	RCM(Restraint Control Module)																										
Ford	Kuga	2.5L	I5	RETM(Rear Entertainment Module)																										
Ford	Kuga	2.5L	I5	RKE(Remote Keyless Entry)																										
Ford	Kuga	2.5L	I5	SRM(Speech Recognition Module)																										
Ford	Kuga	2.5L	I5	TCM(Transmission Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)		V																								
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)			V																							
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)				V	V	V	V	V																		
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Mondeo	2010 MY	2.5L I5	SYSTEM SEARCH																										
Ford	Mondeo	2010 MY	2.5L I5	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2010 MY	2.5L I5	AHCM(Auxiliary Heater Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	BCMii(Body Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CCMii(Cruise Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	CMR(Camera Module Rear)																										
Ford	Mondeo	2010 MY	2.5L I5	DDM(Driver's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	DSM(Driver's Seat Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HCM(Headlamp Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2010 MY	2.5L I5	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PAM(Parking Aid Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PBM(Parking Brake Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PDM(Passenger's Door Module)																										
Ford	Mondeo	2010 MY	2.5L I5	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2010 MY	2.5L I5	RCM(Restraint Control Module)			V																							
Ford	Mondeo	2010 MY	2.5L I5	RFA(Remote Function Actuator)																										
Ford	Mondeo	2010 MY	2.5L I5	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2010 MY	2.5L I5	SRM(Speech Recognition Module)																										
Ford	Mondeo	2010 MY	2.5L I5	TCM(Transmission Control Module)				V	V	V	V	V																		
Ford	Mondeo	2010 MY	2.5L I5	TRM(Trailer Module)																										
Ford	Mondeo	2010 MY	2.5L I5	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SYSTEM SEARCH																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																										
Ford	Mondeo	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	AHCM(Auxiliary Heater Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	BCMii(Body Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CCMii(Cruise Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CMR(Camera Module Rear)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DDM(Driver's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DSM(Driver's Seat Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HCM(HeadLamp Control Module)									V																	
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PAM(Parking Aid Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PBM(Parking Brake Control Module)		V																								
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PDM(Passenger's Door Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RCM(Restraint Control Module)			V																							
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RFA(Remote Function Actuator)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SASM(Steering Angle Sensor Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SRM(Speech Recognition Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TCM(Transmission Control Module)					V	V			V	V	V															
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TRM(Trailer Module)																										
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	VDM(Vehicle Dynamic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SYSTEM SEARCH																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ACM(Audio Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	CDP(Compact Disc Player)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GDM(Generic Display Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GEM(Generic Electronic Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	NAV(Navigation System)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RCM(Restraint Control Module)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RETM(Rear Entertainment Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and installation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																										
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SRM(Speech Recognition Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	SYSTEM SEARCH																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	EATC(Electronic Automatic Temperature Control)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	GEM(Generic Electronic Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	HCM(Headlamp Control Module)																										
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	RCM(Restraint Control Module)																										
Ford	Mondeo	2000 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	2000 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	2000 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	2000 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	2000 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	2000 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	2000 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1999 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1999 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1999 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1999 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1999 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1999 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Mondeo	1998 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	1.8L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1998 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1998 MY	2.0L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.0L	CSM(Central Security Module)																										
Ford	Mondeo	1998 MY	2.5L	SYSTEM SEARCH																										
Ford	Mondeo	1998 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1998 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1998 MY	2.5L	CSM(Central Security Module)																										
Ford	Mondeo	1997 MY	1.8L	SYSTEM SEARCH																										
Ford	Mondeo	1997 MY	1.8L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	1.8L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	1.8L	PATS(Passive Anti Theft System)																										
Ford	Mondeo	1997 MY	1.8L	RIM(Remote Immobilizer Module)																										
Ford	Mondeo	1997 MY	2.0L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Mondeo	1997 MY	2.5L	PCM(PowerTrain Control Module)																										
Ford	Mondeo	1997 MY	2.5L	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	3.7L	TiVCT	BCM-B(Body Control Module B)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Mustang	3.7L	TiVCT	FDIM(Front Display Interface Module)																										
Ford	Mustang	3.7L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Mustang	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Mustang	3.7L	TiVCT	IPC(Instrument Panel Control Module)													V													
Ford	Mustang	3.7L	TiVCT	OCSM(Occupant Classification System Module)																										
Ford	Mustang	3.7L	TiVCT	PAM(Parking Aid Module)																										
Ford	Mustang	3.7L	TiVCT	PSCM(Power Steering Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Mustang	3.8L	SYSTEM SEARCH																											
Ford	Mustang	3.8L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.8L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.8L	GEM(Generic Electronic Module)															V	V											
Ford	Mustang	3.8L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.8L	RCM(Restraint Control Module)																											
Ford	Mustang	3.9L	SYSTEM SEARCH																											
Ford	Mustang	3.9L	PCM(Powertrain Control Module)																											
Ford	Mustang	3.9L	ABS(Anti-Lock Brake System)																											
Ford	Mustang	3.9L	GEM(Generic Electronic Module)															V	V											
Ford	Mustang	3.9L	HEC(Hybrid Electrical Cluster)																											
Ford	Mustang	3.9L	RCM(Restraint Control Module)																											
Ford	Mustang	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	BCM-B(Body Control Module B)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.0L	V6 (SOHC)	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.0L	V6 (SOHC)	IPC(Instrument Panel Control Module)													V													
Ford	Mustang	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Mustang	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Mustang	4.0L	V6 (SOHC)	PAM(Parking Aid Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	PSCM(Power Steering Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Mustang	4.0L	V6 (SOHC)	PATS(Passive Anti Theft System)-BETA																V	V	V	V	V						
Ford	Mustang	4.6L	3V	SYSTEM SEARCH																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	4.6L	3V	BCM-B(Body Control Module B)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	4.6L	3V	FDIM(Front Display Interface Module)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	4.6L	3V	GPSM(Global Positioning System Module)																										
Ford	Mustang	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)													V													
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																										
Ford	Mustang	4.6L	3V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																										
Ford	Mustang	4.6L	3V	PATS(Passive Anti Theft System)-BETA																V	V	V	V	V						
Ford	Mustang	5.0L	~ 2014	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	FDIM(Front Display Interface Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	IPC(Instrument Panel Control Module)												V													
Ford	Mustang	5.0L	~ 2014	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM(Body Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM-B(Body Control Module B)																			V						
Ford	Mustang	5.0L	2015 ~	TiVCT	C-CM(Cruise Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DACM-C(Digital Audio Control Module C)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DDM(Driver's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSM(Driver's Seat Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	GWM(Gateway Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	HUD(Head Up Display)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	ICM(Information Center Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-A(Movable Roof Control Module A)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-B(Movable Roof Control Module B)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PAM(Parking Aid Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PDM(Passenger's Door Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Mustang	5.0L	2015 ~	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	RTM(Radio Transceiver Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SCM-E(Seat Control Module E)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Mustang	5.4L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.4L	4V	BCM-B(Body Control Module B)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.4L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.4L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.4L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.4L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.4L	4V	IPC(Instrument Panel Control Module)													V													
Ford	Mustang	5.4L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.4L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	SYSTEM SEARCH																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	5.8L	4V	BCM-B(Body Control Module B)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																										
Ford	Mustang	5.8L	4V	FDIM(Front Display Interface Module)																										
Ford	Mustang	5.8L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Mustang	5.8L	4V	GPSM(Global Positioning System Module)																										
Ford	Mustang	5.8L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Mustang	5.8L	4V	IPC(Instrument Panel Control Module)													V													
Ford	Mustang	5.8L	4V	OCSM(Occupant Classification System Module)																										
Ford	Mustang	5.8L	4V	PAM(Parking Aid Module)																										
Ford	Mustang	5.8L	4V	PSCM(Power Steering Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM-B(Body Control Module B)																				V						
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ICM(Information Center Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-A(Movable Roof Control Module A)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-B(Movable Roof Control Module B)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																					V					
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																						V				
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																	V						V			
Ford	Ranger	2.5 Diesel(WL-CD)	SYSTEM SEARCH																											
Ford	Ranger	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																										V	V
Ford	Ranger	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																											
Ford	Ranger	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Diesel(WL-CD)	PATS(Passive Anti Theft System)																		V						V			
Ford	Ranger	3.0 Diesel(WE-CD)	SYSTEM SEARCH																											
Ford	Ranger	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																										V	V
Ford	Ranger	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Ranger	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																											
Ford	Ranger	3.0 Diesel(WE-CD)	PATS(Passive Anti Theft System)																			V						V		
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																						V				
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																							V			
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																		V						V		
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SYSTEM SEARCH																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	GEM(Generic Electronic Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	IC(Instrument Cluster)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Ford	Ranger	2.5 Gasoline	SYSTEM SEARCH																											
Ford	Ranger	2.5 Gasoline	PCM(PowerTrain Control Module)																											
Ford	Ranger	2.5 Gasoline	ABS(Anti-Lock Brake System)																								V			
Ford	Ranger	2.5 Gasoline	ACM(Audio Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Ranger	2.5 Gasoline	BCMii(Body Control Module)																											
Ford	Ranger	2.5 Gasoline	DDM(Driver's Door Module)																											
Ford	Ranger	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																											
Ford	Ranger	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																											
Ford	Ranger	2.5 Gasoline	IPC(Instrument Panel Control Module)																											
Ford	Ranger	2.5 Gasoline	PAM(Parking Aid Module)																											
Ford	Ranger	2.5 Gasoline	PDM(Passenger's Door Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																											
Ford	Ranger	2.5 Gasoline	SRM(Speech Recognition Module)																											
Ford	Ranger	2.5 Gasoline	TBM(Tracking And Blocking Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																											
Ford	Ranger	2.5 Gasoline	TRM(Trailer Module)																											
Ford	Ranger	2.5 Gasoline	PATS(Passive Anti Theft System)-BETA																			V						V		
Ford	Ranger	3.0L	Other	SYSTEM SEARCH																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	Other	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	Other	IC(Instrument Cluster)																										
Ford	Ranger	3.0L	Other	OCSM(Occupant Classification System Module)																										
Ford	Ranger	3.0L	Other	4X4(4x4 Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																										
Ford	Ranger	3.0L	Other	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Ranger	3.0L	FFV	SYSTEM SEARCH																										
Ford	Ranger	3.0L	FFV	PCM(Powertrain Control Module)																										
Ford	Ranger	3.0L	FFV	ABS(Anti-Lock Brake System)																										
Ford	Ranger	3.0L	FFV	GEM(Generic Electronic Module)																										
Ford	Ranger	3.0L	FFV	PATS(Passive Anti Theft System)																										
Ford	Ranger	3.0L	FFV	RAP(Remote Anti-Theft/Personality Module)																										
Ford	Ranger	3.0L	FFV	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SYSTEM SEARCH																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatlation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Ranger	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																										
Ford	Ranger	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Ford	Ranger	4.0L	V6 (SOHC)	IC(Instrument Cluster)																										
Ford	Ranger	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	4X4(4x4 Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																										
Ford	Ranger	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																										
Ford	Taurus	3.5L	4V	2008 ~ 2009	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	IC(Instrument Cluster)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	LTM(Liftgate/Trunk Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SECM(Steering Effort Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SYSTEM SEARCH																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HUD(Head Up Display)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	BCM(Body Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Taurus	3.5L	TiVCT	2013 ~	GFM(Generic Function Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HCM(Headlamp Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HSWM(Heated Steering Wheel Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RACM(Rear Audio Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SCCM(Steering Column Control Module)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SYSTEM SEARCH																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	4X4(4x4 Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ACM(Audio Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	C-CM(Cruise Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DDM(Driver's Door Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSM(Driver's Seat Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSP(Digital Signal Processing Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FDIM(Front Display Interface Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GPSM(Global Positioning System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM-2(Headlamp Control Module2)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HUD(Head Up Display)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ILCM(Interior Lighting Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	IPC(Instrument Panel Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PAM(Parking Aid Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PSCM(Power Steering Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RETM(Rear Entertainment Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RFA(Remote Function Actuator)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SASM(Steering Angle Sensor Module)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	3.0L	2000 ~	SYSTEM SEARCH																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	2000 ~	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	2000 ~	EATC(Electronic Automatic Temperature Control)																										
Ford	Taurus	3.0L	2000 ~	GEM(Generic Electronic Module)																										
Ford	Taurus	3.0L	2000 ~	IC(Instrument Cluster)																										
Ford	Taurus	3.0L	2000 ~	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	SYSTEM SEARCH																										
Ford	Taurus	3.0L	~ 1999	PCM(PowerTrain Control Module)																										
Ford	Taurus	3.0L	~ 1999	ABS(Anti-Lock Brake System)																										
Ford	Taurus	3.0L	~ 1999	RCM(Restraint Control Module)																										
Ford	Taurus	3.0L	~ 1999	RIM(Remote Immobilizer Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SYSTEM SEARCH																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PCM(PowerTrain Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ABS(Anti-Lock Brake System)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ACM(Audio Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	GEM(Generic Electronic Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	IC(Instrument Cluster)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PAM(Parking Aid Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	RCM(Restraint Control Module)																										
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SRM(Speech Recognition Module)																										
Ford	Transit	2.0L	2001 ~ 2004	SYSTEM SEARCH																										
Ford	Transit	2.0L	2001 ~ 2004	PCM(PowerTrain Control Module)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.0L	2001 ~ 2004	ASM(Auto Shift Manual)																										
Ford	Transit	2.0L	2001 ~ 2004	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.0L	2001 ~ 2004	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	CSM(Central Security Module)																										
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	SYSTEM SEARCH																										
Ford	Transit	2.4L DIESEL	2006.5	PCM(PowerTrain Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	ABS(Anti-Lock Brake System)																										
Ford	Transit	2.4L DIESEL	2006.5	ACM(Audio Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	BCMii(Body Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	2.4L DIESEL	2006.5	IPC(Instrument Panel Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	PAM(Parking Aid Module)																										
Ford	Transit	2.4L DIESEL	2006.5	RCM(Restraint Control Module)																										
Ford	Transit	2.4L DIESEL	2006.5	TBM(Tracking And Blocking Module)																										
Ford	Transit	2.5L DIESEL	SYSTEM SEARCH																											
Ford	Transit	2.5L DIESEL	PCM(PowerTrain Control Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	ASM(Auto Shift Manual)																											
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																										
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Transit	2.5L DIESEL	RCM(Restraint Control Module)																											
Ford	Transit	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																											
Ford	Transit	2.5L DIESEL	CSM(Central Security Module)																											
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																											
Ford	Transit	2.5L DIESEL	RIM(Remote Immobilizer Module)																											
Ford	Transit	2.5L DIESEL	ACM(Audio Control Module)																											
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Ford	Transit	3.7L	TiVCT	SYSTEM SEARCH																										
Ford	Transit	3.7L	TiVCT	PCM(PowerTrain Control Module)																										
Ford	Transit	3.7L	TiVCT	ABS(Anti-Lock Brake System)																										
Ford	Transit	3.7L	TiVCT	ACM(Audio Control Module)																										
Ford	Transit	3.7L	TiVCT	APIM(Accessory Protocol Control Module)																										
Ford	Transit	3.7L	TiVCT	BCM(Body Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Ford	Transit	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																										
Ford	Transit	3.7L	TiVCT	FCIM(Front Controls Interface Module)																										
Ford	Transit	3.7L	TiVCT	GPSM(Global Positioning System Module)																										
Ford	Transit	3.7L	TiVCT	IPC(Instrument Panel Control Module)																										
Ford	Transit	3.7L	TiVCT	IPM-A(Image Processing Module A)																										
Ford	Transit	3.7L	TiVCT	IPM-B(Image Processing Module B)																										
Ford	Transit	3.7L	TiVCT	PAM(Park Aid Module)																										
Ford	Transit	3.7L	TiVCT	RCM(Restraint Control Module)																										
Ford	Transit	3.7L	TiVCT	SASM(Steering Angle Sensor Module)																										
Ford	Transit	3.7L	TiVCT	TBC(Trailer Brake Control Module)																										
Ford	Transit	3.7L	TiVCT	TRM(Trailer Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																										
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																										
Ford	Thunderbird	3.9L	4V	SYSTEM SEARCH																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																										
Ford	Thunderbird	3.9L	4V	ACM(Audio Control Module)																										
Ford	Thunderbird	3.9L	4V	DDM(Driver's Door Module)																										
Ford	Thunderbird	3.9L	4V	EATC(Electronic Automatic Temperature Control)																										
Ford	Thunderbird	3.9L	4V	GEM(Generic Electronic Module)																										
Ford	Thunderbird	3.9L	4V	HEC(Hybrid Electrical Cluster)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																										
Ford	Thunderbird	3.9L	4V	REM(Rear Electronic Module)																										
Lincoln	Aviator	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Aviator	4.6L	4V	PCM(Powertrain Control Module)																										
Lincoln	Aviator	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Aviator	4.6L	4V	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Aviator	4.6L	4V	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	Aviator	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Aviator	4.6L	4V	IC(Instrument Cluster)																										
Lincoln	Aviator	4.6L	4V	PAM(Parking Aid Module)																										
Lincoln	Aviator	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Aviator	4.6L	4V	TPM(Tire Pressure Monitor)																										
Lincoln	Aviator	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Lincoln	Aviator	4.6L	4V	VSM(Vehicle Security Module)																										
Lincoln	Continental	4.6L	4V	SYSTEM SEARCH																										
Lincoln	Continental	4.6L	4V	PCM(PowerTrain Control Module)																										
Lincoln	Continental	4.6L	4V	ABS(Anti-Lock Brake System)																										
Lincoln	Continental	4.6L	4V	ACM(Audio Control Module)																										
Lincoln	Continental	4.6L	4V	CPM(Cellular Phone Module)																										
Lincoln	Continental	4.6L	4V	DDM(Driver's Door Module)																										
Lincoln	Continental	4.6L	4V	DSM(Driver's Seat Module)																										
Lincoln	Continental	4.6L	4V	LCM(Lighting Control Module)																										
Lincoln	Continental	4.6L	4V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Continental	4.6L	4V	RCM(Restraint Control Module)																										
Lincoln	Continental	4.6L	4V	VDM(Vehicle Dynamic Module)																										
Lincoln	Continental	4.6L	4V	VIC(Virtual Image Cluster)																										
Lincoln	Continental	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Continental	4.6L	4V	PATS(Passive Anti Theft System)																										
Lincoln	LS	ALL	SYSTEM SEARCH																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	PCM(Powertrain Control Module)																											
Lincoln	LS	ALL	ABS(Anti-Lock Brake System)																											
Lincoln	LS	ALL	DCSM(Driver-Dual Climate Control Seat Module)																											
Lincoln	LS	ALL	DDM(Driver's Door Module)																											
Lincoln	LS	ALL	DSM(Driver's Seat Module)																											
Lincoln	LS	ALL	EPB(Electronic Parking Brake)																											
Lincoln	LS	ALL	PAM(Parking Aid Module)																											
Lincoln	LS	ALL	RCM(Restraint Control Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	REM(Rear Electronic Module)																											
Lincoln	LS	ALL	SCLM(Steering Column Locking Module)																											
Lincoln	LS	ALL	EATC(Electronic Automatic Temperature Control)																											
Lincoln	LS	ALL	GEM(Generic Electronic Module)																											
Lincoln	LS	ALL	HEC(Hybrid Electrical Cluster)																											
Lincoln	LS	ALL	PCSM(Passenger Climate Control Seat Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	MKS	3.7L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKS	3.7L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2009	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.7L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2009	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2009	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2009	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SYSTEM SEARCH																									
Lincoln	MKS	3.7L	4V	2010 ~	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	4X4(4x4 Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.7L	4V	2010 ~	ACM(Audio Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DDM(Driver's Door Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	MKS	3.7L	4V	2010 ~	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.7L	4V	2010 ~	HUD(Head Up Display)																									
Lincoln	MKS	3.7L	4V	2010 ~	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.7L	4V	2010 ~	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PAM(Parking Aid Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RCM(Restraint Control Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.7L	4V	2010 ~	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.7L	4V	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM(Power Steering Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SYSTEM SEARCH																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ABS(Anti-Lock Brake System)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	4X4(4x4 Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ACM(Audio Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	C-CM(Cruise Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DDM(Driver's Door Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSM(Driver's Seat Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FDIM(Front Display Interface Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GPSM(Global Positioning System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM(Headlamp Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM-2(Headlamp Control Module2)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HUD(Head Up Display)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ILCM(Interior Lighting Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	IPC(Instrument Panel Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PAM(Parking Aid Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RCM(Restraint Control Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RFA(Remote Function Actuator)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RETM(Rear Entertainment Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SASM(Steering Angle Sensor Module)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKX	3.5L	4V	2007	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2007	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2007	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2007	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2007	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2007	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2007	EATC(Electronic Automatic Temperature Control)																									
Lincoln	MKX	3.5L	4V	2007	GEM(Generic Electronic Module)																									
Lincoln	MKX	3.5L	4V	2007	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2007	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2007	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2007	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2007	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2007	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2007	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2007	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2007	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2008	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2008	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2008	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2008	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2008	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2008	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2008	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2008	HCM(Headlamp Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insalation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	MKX	3.5L	4V	2008	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2008	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2008	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2008	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2008	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2008	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2008	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2008	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2008	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2009	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2009	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2009	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKX	3.5L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2009	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2009	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2009	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2009	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2009	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2009	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2009	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2009	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKX	3.5L	4V	2010	SYSTEM SEARCH																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																									
Lincoln	MKX	3.5L	4V	2010	4X4(4x4 Control Module)																									
Lincoln	MKX	3.5L	4V	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKX	3.5L	4V	2010	ACM(Audio Control Module)																									
Lincoln	MKX	3.5L	4V	2010	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	MKX	3.5L	4V	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSM(Driver's Seat Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKX	3.5L	4V	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKX	3.5L	4V	2010	HCM(Headlamp Control Module)																									
Lincoln	MKX	3.5L	4V	2010	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKX	3.5L	4V	2010	IC(Instrument Cluster)																									
Lincoln	MKX	3.5L	4V	2010	LTM(Liftgate/Trunk Module)																									
Lincoln	MKX	3.5L	4V	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKX	3.5L	4V	2010	PAM(Parking Aid Module)																									
Lincoln	MKX	3.5L	4V	2010	RCM(Restraint Control Module)																									
Lincoln	MKX	3.5L	4V	2010	RETM(Rear Entertainment Module)																									
Lincoln	MKX	3.5L	4V	2010	SASM(Steering Angle Sensor Module)																									
Lincoln	MKX	3.5L	4V	2010	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKZ	3.0L	2006	SYSTEM SEARCH																										
Lincoln	MKZ	3.0L	2006	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.0L	2006	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.0L	2006	ACM(Audio Control Module)																										
Lincoln	MKZ	3.0L	2006	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.0L	2006	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.0L	2006	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.0L	2006	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.0L	2006	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.0L	2006	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.0L	2006	IC(Instrument Cluster)																										
Lincoln	MKZ	3.0L	2006	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.0L	2006	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.0L	2006	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2007	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2007	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2007	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2007	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2007	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2007	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2007	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2007	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	MKZ	3.5L	2007	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2007	EATC(Electronic Automatic Temperature Control)																										
Lincoln	MKZ	3.5L	2007	GEM(Generic Electronic Module)																										
Lincoln	MKZ	3.5L	2007	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2007	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2007	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2007	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2007	PATS(Passive Anti Theft System)																										
Lincoln	MKZ	3.5L	2008	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2008	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2008	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2008	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2008	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2008	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2008	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2008	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2008	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2008	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2008	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2008	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2008	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2008	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2008	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2008	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2009	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2009	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2009	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2009	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2009	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2009	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2009	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2009	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2009	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatlation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	MKZ	3.5L	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2009	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2009	IC(Instrument Cluster)																										
Lincoln	MKZ	3.5L	2009	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2009	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2009	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2009	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	MKZ	3.5L	2009	TCM(Transmission Control Module)																										
Lincoln	MKZ	3.5L	2010	SYSTEM SEARCH																										
Lincoln	MKZ	3.5L	2010	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	3.5L	2010	4X4(4x4 Control Module)																										
Lincoln	MKZ	3.5L	2010	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	3.5L	2010	ACM(Audio Control Module)																										
Lincoln	MKZ	3.5L	2010	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	3.5L	2010	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	MKZ	3.5L	2010	DDM(Driver's Door Module)																										
Lincoln	MKZ	3.5L	2010	DSM(Driver's Seat Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	3.5L	2010	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	3.5L	2010	FDIM(Front Display Interface Module)																										
Lincoln	MKZ	3.5L	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	MKZ	3.5L	2010	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	3.5L	2010	HCM(Headlamp Control Module)																										
Lincoln	MKZ	3.5L	2010	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	MKZ	3.5L	2010	ILCM(Interior Lighting Control Module)																										
Lincoln	MKZ	3.5L	2010	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	3.5L	2010	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	3.5L	2010	PAM(Parking Aid Module)																										
Lincoln	MKZ	3.5L	2010	RCM(Restraint Control Module)																										
Lincoln	MKZ	3.5L	2010	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	3.5L	2010	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	3.5L	2010	TCM(Transmission Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRCM(Transmission Range Control Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM(Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM(Body Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM(Cruise Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM(Driver's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM(Driver's Seat Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM(Gateway Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM(Gear Shift Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM(Headlamp Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD(Head Up Display)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM(Parking Aid Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM(Passenger's Door Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM(Restraint Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM(Rear Gate/Trunk Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G(Seat Control Module G)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H(Seat Control Module H)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM(Transmission Range Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM(Vehicle Dynamic Module)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																										
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM(Generic Function Module)																										
Lincoln	Navigator	2007 ~	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	APIM(Accessory Protocol Interface Module)																										
Lincoln	Navigator	2007 ~	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Lincoln	Navigator	2007 ~	5.4L	GPSM(Global Positioning System Module)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Navigator	2007 ~	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	2007 ~	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	2007 ~	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	2007 ~	5.4L	PRB(Power Running Board)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	RCU(Audio Rear Control Unit)																										
Lincoln	Navigator	2007 ~	5.4L	RETM(Rear Entertainment Module)																										
Lincoln	Navigator	2007 ~	5.4L	SDARS(Satellite Digital Audio Receiver System)																										
Lincoln	Navigator	2007 ~	5.4L	TCCM(Transfer Case Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	TCM(Transmission Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	2007 ~	5.4L	4X4(4x4 Control Module)																										
Lincoln	Navigator	2007 ~	5.4L	PATS(Passive Anti Theft System)																V	V	V	V	V						
Lincoln	Navigator	~ 2007	5.4L	SYSTEM SEARCH																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																										
Lincoln	Navigator	~ 2007	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	DSM(Driver's Seat Module)																										
Lincoln	Navigator	~ 2007	5.4L	GEM(Generic Electronic Module)																										
Lincoln	Navigator	~ 2007	5.4L	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Navigator	~ 2007	5.4L	IC(Instrument Cluster)																										
Lincoln	Navigator	~ 2007	5.4L	LTM(Liftgate/Trunk Module)																										
Lincoln	Navigator	~ 2007	5.4L	PAM(Parking Aid Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																										
Lincoln	Navigator	~ 2007	5.4L	VDM(Vehicle Dynamic Module)																										
Lincoln	Navigator	~ 2007	5.4L	RIM(Remote Immobilizer Module)																										
Lincoln	Navigator	~ 2007	5.4L	VSM(Vehicle Security Module)																										
Lincoln	Town Car	4.6L	2V	SYSTEM SEARCH																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																										
Lincoln	Town Car	4.6L	2V	EATC(Electronic Automatic Temperature Control)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																										
Lincoln	Town Car	4.6L	2V	LCM(Lighting Control Module)																										
Lincoln	Town Car	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Lincoln	Town Car	4.6L	2V	DDM(Driver's Door Module)																										
Lincoln	Town Car	4.6L	2V	DSM(Driver's Seat Module)																										
Lincoln	Town Car	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Lincoln	Town Car	4.6L	2V	RATC(Rear Air Temperature Control)																										
Lincoln	Town Car	4.6L	2V	LTM(Liftgate/Trunk Module)																										
Lincoln	Town Car	4.6L	2V	PAM(Parking Aid Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																										
Lincoln	Town Car	4.6L	2V	HEC(Hybrid Electrical Cluster)																										
Lincoln	Town Car	4.6L	2V	NGSC(Next Generation Speed Control Module)																										
Lincoln	Town Car	4.6L	2V	RASM(Rear Air Suspension Module)																										
Mercury	Grand Marquis	4.6L	2V	SYSTEM SEARCH																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																										
Mercury	Grand Marquis	4.6L	2V	DDM(Driver's Door Module)																										
Mercury	Grand Marquis	4.6L	2V	IC(Instrument Cluster)																										
Mercury	Grand Marquis	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Grand Marquis	4.6L	2V	LCM(Lighting Control Module)																										
Mercury	Grand Marquis	4.6L	2V	MC(Message Center)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																										
Mercury	Grand Marquis	4.6L	2V	RIM(Remote Immobilizer Module)																										
Mercury	Grand Marquis	4.6L	2V	GEM(Generic Electronic Module)																										
Mercury	Grand Marquis	4.6L	2V	VDM(Vehicle Dynamic Module)																										
Mercury	Marauder	4.6L	4V	SYSTEM SEARCH																										
Mercury	Marauder	4.6L	4V	PCM(Powertrain Control Module)																										
Mercury	Marauder	4.6L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Marauder	4.6L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Marauder	4.6L	4V	RASM(Rear Air Suspension Module)																										
Mercury	Marauder	4.6L	4V	VAPS(Variable Assist Power Steering)																										
Mercury	Marauder	4.6L	4V	DDM(Driver's Door Module)																										
Mercury	Marauder	4.6L	4V	LCM(Lighting Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatlation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	Milan	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SYSTEM SEARCH																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Milan	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Milan	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	Milan	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																										
Mercury	Milan	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	Milan	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Milan	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	Milan	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Milan	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Milan	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	Milan	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	Milan	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	Milan	3.0L	4V	TBM(Tracking And Blocking Module)																										
Mercury	Milan	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Milan	3.0L	4V	PATS(Passive Anti Theft System)																										
Mercury	Montego	3.0L	4V	SYSTEM SEARCH																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	Montego	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	Montego	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	Montego	3.0L	4V	ACM(Audio Control Module)																										
Mercury	Montego	3.0L	4V	DSM(Driver's Seat Module)																										
Mercury	Montego	3.0L	4V	EATC(Electronic Automatic Temperature Control)																										
Mercury	Montego	3.0L	4V	GEM(Generic Electronic Module)																										
Mercury	Montego	3.0L	4V	IC(Instrument Cluster)																										
Mercury	Montego	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	Montego	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	Montego	3.0L	4V	TCM(Transmission Control Module)																										
Mercury	FreestarMonterey	3.9L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																											
Mercury	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																											
Mercury	FreestarMonterey	4.2L	SYSTEM SEARCH																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																											
Mercury	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																											
Mercury	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																											
Mercury	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																											
Mercury	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																											
Mercury	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																											
Mercury	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																											
Mercury	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																											
Mercury	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																											
Mercury	Mountaineer	2010 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2010 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2010 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2010 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2010 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2010 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2010 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2010 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2010 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2010 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2010 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2010 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2010 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.6L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	Mountaineer	2009 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2009 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2009 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2009 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2009 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2009 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2009 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2009 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2009 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2009 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2009 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2009 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2009 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2008 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2008 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2008 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2008 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2008 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2008 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2008 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2008 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2008 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2008 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2008 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2008 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	APIM(Accessory Protocol Interface Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	Mountaineer	2007 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2007 MY	4.6L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2007 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2007 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2007 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2007 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2007 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2007 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2007 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2007 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2007 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2007 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2007 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.6L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.6L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	TCM(Transmission Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	APIM(Accessory Protocol Interface Module)																										
Mercury	Mountaineer	2006 MY	4.6L	GPSM(Global Positioning System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	Mountaineer	2006 MY	4.6L	DSM(Driver's Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	Mountaineer	2006 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	Mountaineer	2006 MY	4.6L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.6L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.6L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.6L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.6L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2006 MY	4.0L	SYSTEM SEARCH																										
Mercury	Mountaineer	2006 MY	4.0L	PCM(Powertrain Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	4X4(4x4 Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	DSM(Driver's Seat Module)																										
Mercury	Mountaineer	2006 MY	4.0L	EATC(Electronic Automatic Temperature Control)																										
Mercury	Mountaineer	2006 MY	4.0L	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2006 MY	4.0L	IC(Instrument Cluster)																										
Mercury	Mountaineer	2006 MY	4.0L	OCSM(Occupant Classification System Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2006 MY	4.0L	PRB(Power Running Board)																										
Mercury	Mountaineer	2006 MY	4.0L	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2006 MY	4.0L	RETM(Rear Entertainment Module)																										
Mercury	Mountaineer	2006 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	Mountaineer	2003 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2003 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2003 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2003 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2003 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2003 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2003 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2002 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2002 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2002 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2002 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	Mountaineer	2002 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2002 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2001 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2001 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2001 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2001 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2001 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2001 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	2000 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	2000 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	2000 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	2000 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	2000 MY	GEM(Generic Electronic Module)																											
Mercury	Mountaineer	2000 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																											
Mercury	Mountaineer	1999 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1999 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1999 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1999 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1999 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1999 MY	PAM(Parking Aid Module)																											
Mercury	Mountaineer	1998 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1998 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1998 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1998 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1998 MY	RIM(Remote Immobilizer Module)																											
Mercury	Mountaineer	1997 MY	SYSTEM SEARCH																											
Mercury	Mountaineer	1997 MY	PCM(PowerTrain Control Module)																											
Mercury	Mountaineer	1997 MY	ABS(Anti-Lock Brake System)																											
Mercury	Mountaineer	1997 MY	RCM(Restraint Control Module)																											
Mercury	Mountaineer	1997 MY	RIM(Remote Immobilizer Module)																											

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																										
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																										
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	Module Configuration	RCM Parameter Reset/Configuration	The Installation of a new AT	The Removal and installation of Selector lever	Transmission Fluid Drain and Refill	The Installation of a new TCM	The installation of a new AT with a new TCM	HeadLamp Alignment	The Installation of a new Automatic Transmission with the original TCM	The Removal and insatallation of Selector lever or the Selector lever Cable	The installation of a new automatic transmission with a new TCM	IPC Installation	View Current Remote Transmitter TIC	Reprogram New Remote Transmitter	Customer Spare Key Programming Enable	Customer Spare Key Programming Disable	Parameter reset	Unlimited Key Mode OFF	Unlimited Key Mode ON	BCM-B Module Installation	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	Ignition key code erase and program	MAF Correction	PCM reset
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																										
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Vehicle Info.	Vehicle Info.	Vehicle Info.																											
Ford	Crown Victoria	4.6L	2V	SYSTEM SEARCH																									
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																									
Ford	Crown Victoria	4.6L	2V	PCM(Powertrain Control Module)																									
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																									
Ford	Crown Victoria	4.6L	2V	ABS(Anti-Lock Brake System)																									
Ford	Crown Victoria	4.6L	2V	DDM(Driver's Door Module)																									
Ford	Crown Victoria	4.6L	2V	IC(Instrument Cluster)																									
Ford	Crown Victoria	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Crown Victoria	4.6L	2V	LCM(Lighting Control Module)																									
Ford	Crown Victoria	4.6L	2V	MC(Message Center)																									
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																									
Ford	Crown Victoria	4.6L	2V	RCM(Restraint Control Module)																									
Ford	Crown Victoria	4.6L	2V	RIM(Remote Immobilizer Module)																									
Ford	Crown Victoria	4.6L	2V	GEM(Generic Electronic Module)																									
Ford	Crown Victoria	4.6L	2V	VDM(Vehicle Dynamic Module)																									
Ford	Ecosport	1.0L	ZETEC ROCAM	SYSTEM SEARCH																									
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																									
Ford	Ecosport	1.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																									
Ford	Ecosport	1.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																									
Ford	Ecosport	1.0L	ZETEC ROCAM	GEM(Generic Electronic Module)																									
Ford	Ecosport	1.0L	ZETEC ROCAM	IC(Instrument Cluster)																									
Ford	Ecosport	1.0L	ZETEC ROCAM	RCM(Restraint Control Module)																									
Ford	Ecosport	1.4L	DIESEL	SYSTEM SEARCH																									
Ford	Ecosport	1.4L	DIESEL	PCM(PowerTrain Control Module)																									
Ford	Ecosport	1.4L	DIESEL	ABS(Anti-Lock Brake System)																									
Ford	Ecosport	1.4L	DIESEL	GEM(Generic Electronic Module)																									
Ford	Ecosport	1.4L	DIESEL	IC(Instrument Cluster)																									
Ford	Ecosport	1.4L	DIESEL	RCM(Restraint Control Module)																									
Ford	Ecosport	1.6L	ZETEC ROCAM	SYSTEM SEARCH																									
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																									
Ford	Ecosport	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																									
Ford	Ecosport	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																									
Ford	Ecosport	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																									
Ford	Ecosport	1.6L	ZETEC ROCAM	IC(Instrument Cluster)																									
Ford	Ecosport	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																									
Ford	Ecosport	1.6L	FFV	SYSTEM SEARCH																									
Ford	Ecosport	1.6L	FFV	PCM(PowerTrain Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Ecosport	1.6L	FFV	ABS(Anti-Lock Brake System)																									
Ford	Ecosport	1.6L	FFV	GEM(Generic Electronic Module)																									
Ford	Ecosport	1.6L	FFV	IC(Instrument Cluster)																									
Ford	Ecosport	1.6L	FFV	RCM(Restraint Control Module)																									
Ford	Ecosport	1.6L	FFV	TBM(Tracking And Blocking Module)																									
Ford	Ecosport	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																									
Ford	Ecosport	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Ford	Ecosport	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Ecosport	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																									
Ford	Ecosport	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																									
Ford	Ecosport	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	Ecosport	2.0L	ZETEC ROCAM	SYSTEM SEARCH																									
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																									
Ford	Ecosport	2.0L	ZETEC ROCAM	PCM(PowerTrain Control Module)																									
Ford	Ecosport	2.0L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																									
Ford	Ecosport	2.0L	ZETEC ROCAM	IC(Instrument Cluster)																									
Ford	Ecosport	2.0L	ZETEC ROCAM	RCM(Restraint Control Module)																									
Ford	Ecosport	2.0L	FFV	SYSTEM SEARCH																									
Ford	Ecosport	2.0L	FFV	PCM(PowerTrain Control Module)																									
Ford	Ecosport	2.0L	FFV	ABS(Anti-Lock Brake System)																									
Ford	Ecosport	2.0L	FFV	GEM(Generic Electronic Module)																									
Ford	Ecosport	2.0L	FFV	IC(Instrument Cluster)																									
Ford	Ecosport	2.0L	FFV	RCM(Restraint Control Module)																									
Ford	Ecosport	2.0L	FFV	TBM(Tracking And Blocking Module)																									
Ford	Escort	2.0L	SYSTEM SEARCH																										
Ford	Escort	2.0L	PCM(PowerTrain Control Module)																										
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Escort	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Escort	2.0L	ECS(Electronic Crash Sensor)																										
Ford	Escort	2.0L	PATS(Passive Anti Theft System)																										
Ford	Escort	2.0L	RAP(Remote Anti-Theft/Personality Module)																										
Ford	Edge	3.5L	4V	SYSTEM SEARCH																									
Ford	Edge	3.5L	4V	PCM(PowerTrain Control Module)																									
Ford	Edge	3.5L	4V	4X4(4x4 Control Module)																									
Ford	Edge	3.5L	4V	ABS(Anti-Lock Brake System)																									
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																									
Ford	Edge	3.5L	4V	ACM(Audio Control Module)																									
Ford	Edge	3.5L	4V	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Edge	3.5L	4V	DSM(Driver's Seat Module)																									
Ford	Edge	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Edge	3.5L	4V	GPSM(Global Positioning System Module)																									
Ford	Edge	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Edge	3.5L	4V	IC(Instrument Cluster)																									
Ford	Edge	3.5L	4V	LTM(Liftgate/Trunk Module)																									
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																									
Ford	Edge	3.5L	4V	OCSM(Occupant Classification System Module)																									
Ford	Edge	3.5L	4V	PAM(Parking Aid Module)																									
Ford	Edge	3.5L	4V	RCM(Restraint Control Module)																									
Ford	Edge	3.5L	4V	RETM(Rear Entertainment Module)																									
Ford	Edge	3.5L	4V	SASM(Steering Angle Sensor Module)																									
Ford	Edge	3.5L	4V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Edge	3.5L	4V	TBM(Tracking And Blocking Module)																									
Ford	Edge	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Edge	3.5L	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Edge	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Edge	3.5L	TiVCT	ACM(Audio Control Module)																									
Ford	Edge	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Edge	3.5L	TiVCT	BCM(Body Control Module)																									
Ford	Edge	3.5L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Edge	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Edge	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Edge	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Edge	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Edge	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Edge	3.5L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Edge	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Edge	3.5L	TiVCT	HUD(Head Up Display)																									
Ford	Edge	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Edge	3.5L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Edge	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Edge	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Edge	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Edge	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Edge	3.5L	TiVCT	RFA(Remote Function Actuator)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Edge	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Edge	3.5L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Edge	3.5L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Edge	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Edge	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Edge	3.5L	TiVCT	PATS(Passive Anti Theft System)																									
Ford	Edge	3.7L	TiVCT	SYSTEM SEARCH																									
Ford	Edge	3.7L	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Edge	3.7L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Edge	3.7L	TiVCT	ACM(Audio Control Module)																									
Ford	Edge	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Edge	3.7L	TiVCT	BCM(Body Control Module)																									
Ford	Edge	3.7L	TiVCT	C-CM(Cruise Control Module)																									
Ford	Edge	3.7L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Edge	3.7L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Edge	3.7L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Edge	3.7L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Edge	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Edge	3.7L	TiVCT	FLM(Front Lighting Control Module)																									
Ford	Edge	3.7L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Edge	3.7L	TiVCT	HUD(Head Up Display)																									
Ford	Edge	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Edge	3.7L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Edge	3.7L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Edge	3.7L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Edge	3.7L	TiVCT	PAM(Parking Aid Module)																									
Ford	Edge	3.7L	TiVCT	RCM(Restraint Control Module)																									
Ford	Edge	3.7L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Edge	3.7L	TiVCT	RLCM-A(Rear Lighting Control Module A)																									
Ford	Edge	3.7L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	Edge	3.7L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	Edge	3.7L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Edge	3.7L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Edge	3.7L	TiVCT	TBM(Tracking And Blocking Module)																									
Ford	Edge	3.7L	TiVCT	PATS(Passive Anti Theft System)																									
Ford	Escape	Up to 2004	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Escape	Up to 2004	PCM(PowerTrain Control Module)																										
Ford	Escape	Up to 2004	Immobilizer																										
Ford	Escape	Up to 2004	ABS(Anti-Lock Brake System)																										
Ford	Escape	Up to 2004	RCM(Restraint Control Module)																										
Ford	Escape	Up to 2004	GEM(Generic Electronic Module)																										
Ford	Escape	From 2004	SYSTEM SEARCH																										
Ford	Escape	From 2004	PCM(PowerTrain Control Module)																										
Ford	Escape	From 2004	PATS(Passive Anti Theft System)																										
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																										
Ford	Escape	From 2004	ABS(Anti-Lock Brake System)																										
Ford	Escape	From 2004	RCM(Restraint Control Module)																										
Ford	Escape	From 2004	IC(Instrument cluster)																										
Ford	Escape	From 2004	GEM(Generic Electronic Module)																										
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																									
Ford	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																									
Ford	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																									
Ford	Excursion	GASOLINE	SYSTEM SEARCH																										
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Excursion	GASOLINE	PCM(Powertrain Control Module)																										
Ford	Excursion	GASOLINE	ABS(Anti-Lock Brake System)																										
Ford	Excursion	GASOLINE	CSM(Central Security Module)																										
Ford	Excursion	GASOLINE	DSM(Driver's Seat Module)																										
Ford	Excursion	GASOLINE	EATC(Electronic Automatic Temperature Control)																										
Ford	Excursion	GASOLINE	ECS(Electronic Crash Sensor)																										
Ford	Excursion	GASOLINE	GEM(Generic Electronic Module)																										
Ford	Excursion	GASOLINE	HEC(Hybrid Electrical Cluster)																										
Ford	Excursion	GASOLINE	OTC(Overhead Trip Computer)																										
Ford	Excursion	GASOLINE	PAM(Parking Aid Module)																										
Ford	Excursion	GASOLINE	PATS(Passive Anti Theft System)																										
Ford	Excursion	GASOLINE	TCM(Transmission Control Module)																										
Ford	Excursion	GASOLINE	VSM(Vehicle Security Module)																										
Ford	Excursion	DIESEL	SYSTEM SEARCH																										
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																										
Ford	Excursion	DIESEL	PCM(Powertrain Control Module)																										
Ford	Excursion	DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Excursion	DIESEL	CSM(Central Security Module)																										
Ford	Excursion	DIESEL	DSM(Driver's Seat Module)																										
Ford	Excursion	DIESEL	EATC(Electronic Automatic Temperature Control)																										
Ford	Excursion	DIESEL	ECS(Electronic Crash Sensor)																										
Ford	Excursion	DIESEL	GEM(Generic Electronic Module)																										
Ford	Excursion	DIESEL	HEC(Hybrid Electrical Cluster)																										
Ford	Excursion	DIESEL	OTC(Overhead Trip Computer)																										
Ford	Excursion	DIESEL	PAM(Parking Aid Module)																										
Ford	Excursion	DIESEL	PATS(Passive Anti Theft System)																										
Ford	Excursion	DIESEL	TCM(Transmission Control Module)																										
Ford	Excursion	DIESEL	VSM(Vehicle Security Module)																										
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SYSTEM SEARCH																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PCM(Powertrain Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ABS(Anti-Lock Brake System)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	ACM(Audio Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	APIM(Accessory Protocol Interface Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DCSM(Driver-Dual Climate Control Seat Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSM(Driver's Seat Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	DSP(Digital Signal Processing Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	EATC(Electronic Automatic Temperature Control)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	IC(Instrument Cluster)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	LTM(Liftgate/Trunk Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PAM(Parking Aid Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PRB(Power Running Board)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCM(Restraint Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RCU(Audio Rear Control Unit)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	RETM(Rear Entertainment Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	SDARS(Satellite Digital Audio Receiver System)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	TCM(Transmission Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VDM(Vehicle Dynamic Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	4X4(4x4 Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	PATS(Passive Anti Theft System)																								
Ford	ExpeditionExpedition EL	5.4L	3V	~ 2007	VSM(Vehicle Security Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SYSTEM SEARCH																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PCM(Powertrain Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ABS(Anti-Lock Brake System)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	ACM(Audio Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	APIM(Accessory Protocol Interface Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSM(Driver's Seat Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	DSP(Digital Signal Processing Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	GPSM(Global Positioning System Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	HVAC(Heating Ventilation Air Conditioning)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	IC(Instrument Cluster)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	LTM(Liftgate/Trunk Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PAM(Parking Aid Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PRB(Power Running Board)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCM(Restraint Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RCU(Audio Rear Control Unit)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	RETM(Rear Entertainment Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	SDARS(Satellite Digital Audio Receiver System)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TBC(Trailer Brake Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCCM(Transfer Case Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	TCM(Transmission Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	VDM(Vehicle Dynamic Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	4X4(4x4 Control Module)																								
Ford	ExpeditionExpedition EL	5.4L	3V	2008 ~	PATS(Passive Anti Theft System)																								
Ford	ExpeditionExpedition EL	5.4L	2V	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	2V	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	2V	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	5.4L	2V	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	2V	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	5.4L	2V	GEM(Generic Electronic Module)																									
Ford	ExpeditionExpedition EL	5.4L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	ExpeditionExpedition EL	5.4L	2V	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	5.4L	2V	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	2V	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	5.4L	2V	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	5.4L	2V	RIM(Remote Immobilizer Module)																									
Ford	ExpeditionExpedition EL	5.4L	2V	VSM(Vehicle Security Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	SYSTEM SEARCH																									
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	ExpeditionExpedition EL	4.6L	2V	PCM(Powertrain Control Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	4.6L	2V	ABS(Anti-Lock Brake System)																									
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	ACM(Audio Control Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	APIM(Accessory Protocol Interface Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	DSM(Driver's Seat Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	DSP(Digital Signal Processing Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	4.6L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	ExpeditionExpedition EL	4.6L	2V	GPSM(Global Positioning System Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	EATC(Electronic Automatic Temperature Control)																									
Ford	ExpeditionExpedition EL	4.6L	2V	IC(Instrument Cluster)																									
Ford	ExpeditionExpedition EL	4.6L	2V	LTM(Liftgate/Trunk Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	PRB(Power Running Board)																									
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	RCM(Restraint Control Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	RCU(Audio Rear Control Unit)																									
Ford	ExpeditionExpedition EL	4.6L	2V	RETM(Rear Entertainment Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	ExpeditionExpedition EL	4.6L	2V	TCM(Transmission Control Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	4X4(4x4 Control Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	RIM(Remote Immobilizer Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	PAM(Parking Aid Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	VDM(Vehicle Dynamic Module)																									
Ford	ExpeditionExpedition EL	4.6L	2V	VSM(Vehicle Security Module)																									
Ford	Explorer	2015 MY	3.5L	TiVCT	SYSTEM SEARCH																								
Ford	Explorer	2015 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	ACM(Audio Control Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	BCM(Body Control Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2015 MY	3.5L	TiVCT	CLM(Column Lock Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	HUD(Head Up Display)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	PAM(Parking Aid Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	RCM(Restraint Control Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Explorer	2015 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Explorer	2015 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	SYSTEM SEARCH																								
Ford	Explorer	2014 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	ACM(Audio Control Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	BCM(Body Control Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	CLM(Column Lock Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	HUD(Head Up Display)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2014 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	PAM(Parking Aid Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	RCM(Restraint Control Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Explorer	2014 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Explorer	2014 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	SYSTEM SEARCH																								
Ford	Explorer	2013 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	ACM(Audio Control Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	BCM(Body Control Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	CLM(Column Lock Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	HUD(Head Up Display)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	PAM(Parking Aid Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	RCM(Restraint Control Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2013 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																								
Ford	Explorer	2013 MY	3.5L	TiVCT	PATS(Passive Anti Theft System)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Explorer	2013 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	SYSTEM SEARCH																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2012 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	ACM(Audio Control Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	BCM(Body Control Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	CLM(Column Lock Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	HUD(Head Up Display)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	PAM(Parking Aid Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	RCM(Restraint Control Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Explorer	2012 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Explorer	2012 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	SYSTEM SEARCH																								
Ford	Explorer	2011 MY	3.5L	TiVCT	PCM(Powertrain Control Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	ACM(Audio Control Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	BCM(Body Control Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	ATCM(All Terrain Control Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	C-CM(Cruise Control Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	CLM(Column Lock Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	DSM(Driver's Seat Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	FCDIM(Front Control/Display Interface Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	FLM(Front Lighting Control Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	GPSM(Global Positioning System Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	HUD(Head Up Display)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	IPC(Instrument Panel Control Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	PAM(Parking Aid Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	PSCM(Power Steering Control Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	RCM(Restraint Control Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	RFA(Remote Function Actuator)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	RLCM-A(Rear Lighting Control Module A)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	SCCM(Steering Column Control Module)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Explorer	2011 MY	3.5L	TiVCT	TPM(Tire Pressure Monitor)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM(Transmission Control Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM(All Terrain Control Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM(Column Lock Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM(Front Lighting Control Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A(Rear Lighting Control Module A)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Explorer	2011 MY	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Explorer	2010 MY	4.0L	2V	SYSTEM SEARCH																								
Ford	Explorer	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																								
Ford	Explorer	2010 MY	4.0L	2V	TCM(Transmission Control Module)																								
Ford	Explorer	2010 MY	4.0L	2V	4X4(4x4 Control Module)																								
Ford	Explorer	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer	2010 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																								
Ford	Explorer	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																								
Ford	Explorer	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Explorer	2010 MY	4.0L	2V	IC(Instrument Cluster)																								
Ford	Explorer	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2010 MY	4.0L	2V	PAM(Parking Aid Module)																								
Ford	Explorer	2010 MY	4.0L	2V	PRB(Power Running Board)																								
Ford	Explorer	2010 MY	4.0L	2V	RCM(Restraint Control Module)																								
Ford	Explorer	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																								
Ford	Explorer	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																								
Ford	Explorer	2010 MY	4.6L	3V	SYSTEM SEARCH																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																								
Ford	Explorer	2010 MY	4.6L	3V	TCM(Transmission Control Module)																								
Ford	Explorer	2010 MY	4.6L	3V	4X4(4x4 Control Module)																								
Ford	Explorer	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2010 MY	4.6L	3V	ACM(Audio Control Module)																								
Ford	Explorer	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																								
Ford	Explorer	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																								
Ford	Explorer	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Explorer	2010 MY	4.6L	3V	IC(Instrument Cluster)																								
Ford	Explorer	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2010 MY	4.6L	3V	PAM(Parking Aid Module)																								
Ford	Explorer	2010 MY	4.6L	3V	PRB(Power Running Board)																								
Ford	Explorer	2010 MY	4.6L	3V	RCM(Restraint Control Module)																								
Ford	Explorer	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																								
Ford	Explorer	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer	2009 MY	4.0L	2V	SYSTEM SEARCH																								
Ford	Explorer	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																								
Ford	Explorer	2009 MY	4.0L	2V	TCM(Transmission Control Module)																								
Ford	Explorer	2009 MY	4.0L	2V	4X4(4x4 Control Module)																								
Ford	Explorer	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer	2009 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																								
Ford	Explorer	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																								
Ford	Explorer	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Explorer	2009 MY	4.0L	2V	IC(Instrument Cluster)																								
Ford	Explorer	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2009 MY	4.0L	2V	PAM(Parking Aid Module)																								
Ford	Explorer	2009 MY	4.0L	2V	PRB(Power Running Board)																								
Ford	Explorer	2009 MY	4.0L	2V	RCM(Restraint Control Module)																								
Ford	Explorer	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																								
Ford	Explorer	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																								
Ford	Explorer	2009 MY	4.6L	3V	SYSTEM SEARCH																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																								
Ford	Explorer	2009 MY	4.6L	3V	TCM(Transmission Control Module)																								
Ford	Explorer	2009 MY	4.6L	3V	4X4(4x4 Control Module)																								
Ford	Explorer	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2009 MY	4.6L	3V	ACM(Audio Control Module)																								
Ford	Explorer	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																								
Ford	Explorer	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																								
Ford	Explorer	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Explorer	2009 MY	4.6L	3V	IC(Instrument Cluster)																								
Ford	Explorer	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2009 MY	4.6L	3V	PAM(Parking Aid Module)																								
Ford	Explorer	2009 MY	4.6L	3V	PRB(Power Running Board)																								
Ford	Explorer	2009 MY	4.6L	3V	RCM(Restraint Control Module)																								
Ford	Explorer	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																								
Ford	Explorer	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer	2008 MY	4.0L	2V	SYSTEM SEARCH																								
Ford	Explorer	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																								
Ford	Explorer	2008 MY	4.0L	2V	TCM(Transmission Control Module)																								
Ford	Explorer	2008 MY	4.0L	2V	4X4(4x4 Control Module)																								
Ford	Explorer	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2008 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																								
Ford	Explorer	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																								
Ford	Explorer	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																								
Ford	Explorer	2008 MY	4.0L	2V	IC(Instrument Cluster)																								
Ford	Explorer	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2008 MY	4.0L	2V	PAM(Parking Aid Module)																								
Ford	Explorer	2008 MY	4.0L	2V	PRB(Power Running Board)																								
Ford	Explorer	2008 MY	4.0L	2V	RCM(Restraint Control Module)																								
Ford	Explorer	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																								
Ford	Explorer	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer	2008 MY	4.6L	3V	SYSTEM SEARCH																								
Ford	Explorer	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																								
Ford	Explorer	2008 MY	4.6L	3V	TCM(Transmission Control Module)																								
Ford	Explorer	2008 MY	4.6L	3V	4X4(4x4 Control Module)																								
Ford	Explorer	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2008 MY	4.6L	3V	ACM(Audio Control Module)																								
Ford	Explorer	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																								
Ford	Explorer	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																								
Ford	Explorer	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																								
Ford	Explorer	2008 MY	4.6L	3V	IC(Instrument Cluster)																								
Ford	Explorer	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2008 MY	4.6L	3V	PAM(Parking Aid Module)																								
Ford	Explorer	2008 MY	4.6L	3V	PRB(Power Running Board)																								
Ford	Explorer	2008 MY	4.6L	3V	RCM(Restraint Control Module)																								
Ford	Explorer	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																								
Ford	Explorer	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer	2007 MY	4.0L	2V	SYSTEM SEARCH																								
Ford	Explorer	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																								
Ford	Explorer	2007 MY	4.0L	2V	TCM(Transmission Control Module)																								
Ford	Explorer	2007 MY	4.0L	2V	4X4(4x4 Control Module)																								
Ford	Explorer	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2007 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																								
Ford	Explorer	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																								
Ford	Explorer	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																								
Ford	Explorer	2007 MY	4.0L	2V	IC(Instrument Cluster)																								
Ford	Explorer	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2007 MY	4.0L	2V	PAM(Parking Aid Module)																								
Ford	Explorer	2007 MY	4.0L	2V	PRB(Power Running Board)																								
Ford	Explorer	2007 MY	4.0L	2V	RCM(Restraint Control Module)																								
Ford	Explorer	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																								
Ford	Explorer	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer	2007 MY	4.6L	3V	SYSTEM SEARCH																								
Ford	Explorer	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																								
Ford	Explorer	2007 MY	4.6L	3V	TCM(Transmission Control Module)																								
Ford	Explorer	2007 MY	4.6L	3V	4X4(4x4 Control Module)																								
Ford	Explorer	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2007 MY	4.6L	3V	ACM(Audio Control Module)																								
Ford	Explorer	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																								
Ford	Explorer	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																								
Ford	Explorer	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																								
Ford	Explorer	2007 MY	4.6L	3V	IC(Instrument Cluster)																								
Ford	Explorer	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2007 MY	4.6L	3V	PAM(Parking Aid Module)																								
Ford	Explorer	2007 MY	4.6L	3V	PRB(Power Running Board)																								
Ford	Explorer	2007 MY	4.6L	3V	RCM(Restraint Control Module)																								
Ford	Explorer	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																								
Ford	Explorer	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer	2006 MY	4.0L	2V	SYSTEM SEARCH																								
Ford	Explorer	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																								
Ford	Explorer	2006 MY	4.0L	2V	TCM(Transmission Control Module)																								
Ford	Explorer	2006 MY	4.0L	2V	4X4(4x4 Control Module)																								
Ford	Explorer	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2006 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																								
Ford	Explorer	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																								
Ford	Explorer	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																								
Ford	Explorer	2006 MY	4.0L	2V	IC(Instrument Cluster)																								
Ford	Explorer	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2006 MY	4.0L	2V	PAM(Parking Aid Module)																								
Ford	Explorer	2006 MY	4.0L	2V	PRB(Power Running Board)																								
Ford	Explorer	2006 MY	4.0L	2V	RCM(Restraint Control Module)																								
Ford	Explorer	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																								
Ford	Explorer	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer	2006 MY	4.6L	3V	SYSTEM SEARCH																								
Ford	Explorer	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																								
Ford	Explorer	2006 MY	4.6L	3V	TCM(Transmission Control Module)																								
Ford	Explorer	2006 MY	4.6L	3V	4X4(4x4 Control Module)																								
Ford	Explorer	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																								
Ford	Explorer	2006 MY	4.6L	3V	ACM(Audio Control Module)																								
Ford	Explorer	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																								
Ford	Explorer	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																								
Ford	Explorer	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																								
Ford	Explorer	2006 MY	4.6L	3V	IC(Instrument Cluster)																								
Ford	Explorer	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																								
Ford	Explorer	2006 MY	4.6L	3V	PAM(Parking Aid Module)																								
Ford	Explorer	2006 MY	4.6L	3V	PRB(Power Running Board)																								
Ford	Explorer	2006 MY	4.6L	3V	RCM(Restraint Control Module)																								
Ford	Explorer	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																								
Ford	Explorer	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer	2005 MY	SYSTEM SEARCH																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																										
Ford	Explorer	2005 MY	PCM(PowerTrain Control Module)																										
Ford	Explorer	2005 MY	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2005 MY	PAM(Parking Aid Module)																										
Ford	Explorer	2005 MY	4X4(4x4 Control Module)																										
Ford	Explorer	2005 MY	HEC(Hybrid Electrical Cluster)																										
Ford	Explorer	2005 MY	RCM(Restraint Control Module)																										
Ford	Explorer	2005 MY	VSM(Vehicle Security Module)																										
Ford	Explorer	2004 MY	SYSTEM SEARCH																										
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																										
Ford	Explorer	2004 MY	PCM(PowerTrain Control Module)																										
Ford	Explorer	2004 MY	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2004 MY	PAM(Parking Aid Module)																										
Ford	Explorer	2004 MY	4X4(4x4 Control Module)																										
Ford	Explorer	2004 MY	HEC(Hybrid Electrical Cluster)																										
Ford	Explorer	2004 MY	RCM(Restraint Control Module)																										
Ford	Explorer	2004 MY	VSM(Vehicle Security Module)																										
Ford	Explorer	2003 MY	SYSTEM SEARCH																										
Ford	Explorer	2003 MY	PCM(PowerTrain Control Module)																										
Ford	Explorer	2003 MY	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2003 MY	PAM(Parking Aid Module)																										
Ford	Explorer	2003 MY	4X4(4x4 Control Module)																										
Ford	Explorer	2003 MY	HEC(Hybrid Electrical Cluster)																										
Ford	Explorer	2003 MY	RCM(Restraint Control Module)																										
Ford	Explorer	2003 MY	VSM(Vehicle Security Module)																										
Ford	Explorer	2002 MY	SYSTEM SEARCH																										
Ford	Explorer	2002 MY	PCM(PowerTrain Control Module)																										
Ford	Explorer	2002 MY	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2002 MY	PAM(Parking Aid Module)																										
Ford	Explorer	2002 MY	4X4(4x4 Control Module)																										
Ford	Explorer	2002 MY	HEC(Hybrid Electrical Cluster)																										
Ford	Explorer	2002 MY	RCM(Restraint Control Module)																										
Ford	Explorer	2002 MY	VSM(Vehicle Security Module)																										
Ford	Explorer	2001 MY	SYSTEM SEARCH																										
Ford	Explorer	2001 MY	PCM(PowerTrain Control Module)																										
Ford	Explorer	2001 MY	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2001 MY	RCM(Restraint Control Module)																										
Ford	Explorer	2001 MY	RIM(Remote Immobilizer Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer	2001 MY	GEM(Generic Electronic Module)																										
Ford	Explorer	2001 MY	PAM(Parking Aid Module)																										
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																										
Ford	Explorer	2001 MY	PATS(Passive Anti Theft System)																										
Ford	Explorer	2000 MY	SYSTEM SEARCH																										
Ford	Explorer	2000 MY	PCM(PowerTrain Control Module)																										
Ford	Explorer	2000 MY	ABS(Anti-Lock Brake System)																										
Ford	Explorer	2000 MY	RCM(Restraint Control Module)																										
Ford	Explorer	2000 MY	RIM(Remote Immobilizer Module)																										
Ford	Explorer	2000 MY	GEM(Generic Electronic Module)																										
Ford	Explorer	2000 MY	PAM(Parking Aid Module)																										
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																										
Ford	Explorer	2000 MY	PATS(Passive Anti Theft System)																										
Ford	Explorer	1999 MY	SYSTEM SEARCH																										
Ford	Explorer	1999 MY	PCM(PowerTrain Control Module)																										
Ford	Explorer	1999 MY	ABS(Anti-Lock Brake System)																										
Ford	Explorer	1999 MY	RCM(Restraint Control Module)																										
Ford	Explorer	1999 MY	RIM(Remote Immobilizer Module)																										
Ford	Explorer	1999 MY	PAM(Parking Aid Module)																										
Ford	Explorer	1998 MY	SYSTEM SEARCH																										
Ford	Explorer	1998 MY	PCM(PowerTrain Control Module)																										
Ford	Explorer	1998 MY	ABS(Anti-Lock Brake System)																										
Ford	Explorer	1998 MY	RCM(Restraint Control Module)																										
Ford	Explorer	1998 MY	RIM(Remote Immobilizer Module)																										
Ford	Explorer	1997 MY	SYSTEM SEARCH																										
Ford	Explorer	1997 MY	PCM(PowerTrain Control Module)																										
Ford	Explorer	1997 MY	ABS(Anti-Lock Brake System)																										
Ford	Explorer	1997 MY	RCM(Restraint Control Module)																										
Ford	Explorer	1997 MY	RIM(Remote Immobilizer Module)																										
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SYSTEM SEARCH																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PCM(Powertrain Control Module)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	TCM(Transmission Control Module)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	4X4(4x4 Control Module)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ABS(Anti-Lock Brake System)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GPSM(Global Positioning System Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer SportTrac	2010 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	DSM(Driver's Seat Module)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	IC(Instrument Cluster)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	OCSM(Occupant Classification System Module)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PAM(Parking Aid Module)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PRB(Power Running Board)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RCM(Restraint Control Module)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	RETM(Rear Entertainment Module)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer SportTrac	2010 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SYSTEM SEARCH																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PCM(Powertrain Control Module)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	TCM(Transmission Control Module)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	4X4(4x4 Control Module)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ABS(Anti-Lock Brake System)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	ACM(Audio Control Module)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GPSM(Global Positioning System Module)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	DSM(Driver's Seat Module)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	IC(Instrument Cluster)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	OCSM(Occupant Classification System Module)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PAM(Parking Aid Module)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	PRB(Power Running Board)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RCM(Restraint Control Module)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	RETM(Rear Entertainment Module)																								
Ford	Explorer SportTrac	2010 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SYSTEM SEARCH																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PCM(Powertrain Control Module)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	TCM(Transmission Control Module)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	4X4(4x4 Control Module)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ABS(Anti-Lock Brake System)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GPSM(Global Positioning System Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer SportTrac	2009 MY	4.0L	2V	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	DSM(Driver's Seat Module)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	IC(Instrument Cluster)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	OCSM(Occupant Classification System Module)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PAM(Parking Aid Module)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PRB(Power Running Board)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RCM(Restraint Control Module)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	RETM(Rear Entertainment Module)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer SportTrac	2009 MY	4.0L	2V	PATS(Passive Anti Theft System)-BETA																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SYSTEM SEARCH																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PCM(Powertrain Control Module)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	TCM(Transmission Control Module)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	4X4(4x4 Control Module)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ABS(Anti-Lock Brake System)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	ACM(Audio Control Module)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	APIM(Accessory Protocol Interface Module)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GPSM(Global Positioning System Module)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	DSM(Driver's Seat Module)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	IC(Instrument Cluster)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	OCSM(Occupant Classification System Module)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PAM(Parking Aid Module)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	PRB(Power Running Board)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RCM(Restraint Control Module)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	RETM(Rear Entertainment Module)																								
Ford	Explorer SportTrac	2009 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SYSTEM SEARCH																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PCM(Powertrain Control Module)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	TCM(Transmission Control Module)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	4X4(4x4 Control Module)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ABS(Anti-Lock Brake System)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	DSM(Driver's Seat Module)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	GEM(Generic Electronic Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer SportTrac	2008 MY	4.0L	2V	IC(Instrument Cluster)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	OCSM(Occupant Classification System Module)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PAM(Parking Aid Module)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	PRB(Power Running Board)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RCM(Restraint Control Module)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	RETM(Rear Entertainment Module)																								
Ford	Explorer SportTrac	2008 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SYSTEM SEARCH																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PCM(Powertrain Control Module)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	TCM(Transmission Control Module)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	4X4(4x4 Control Module)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ABS(Anti-Lock Brake System)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	ACM(Audio Control Module)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	DSM(Driver's Seat Module)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	GEM(Generic Electronic Module)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	IC(Instrument Cluster)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	OCSM(Occupant Classification System Module)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PAM(Parking Aid Module)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	PRB(Power Running Board)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RCM(Restraint Control Module)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	RETM(Rear Entertainment Module)																								
Ford	Explorer SportTrac	2008 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SYSTEM SEARCH																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PCM(Powertrain Control Module)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	TCM(Transmission Control Module)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	4X4(4x4 Control Module)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ABS(Anti-Lock Brake System)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	DSM(Driver's Seat Module)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	GEM(Generic Electronic Module)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	IC(Instrument Cluster)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	OCSM(Occupant Classification System Module)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PAM(Parking Aid Module)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	PRB(Power Running Board)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RCM(Restraint Control Module)																								
Ford	Explorer SportTrac	2007 MY	4.0L	2V	RETM(Rear Entertainment Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer SportTrac	2007 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SYSTEM SEARCH																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PCM(Powertrain Control Module)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	TCM(Transmission Control Module)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	4X4(4x4 Control Module)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ABS(Anti-Lock Brake System)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	ACM(Audio Control Module)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	DSM(Driver's Seat Module)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	GEM(Generic Electronic Module)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	IC(Instrument Cluster)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	OCSM(Occupant Classification System Module)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PAM(Parking Aid Module)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	PRB(Power Running Board)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RCM(Restraint Control Module)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	RETM(Rear Entertainment Module)																								
Ford	Explorer SportTrac	2007 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SYSTEM SEARCH																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PCM(Powertrain Control Module)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	TCM(Transmission Control Module)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	4X4(4x4 Control Module)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ABS(Anti-Lock Brake System)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	ACM(Audio Control Module)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	DSM(Driver's Seat Module)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	EATC(Electronic Automatic Temperature Control)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	GEM(Generic Electronic Module)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	IC(Instrument Cluster)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	OCSM(Occupant Classification System Module)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PAM(Parking Aid Module)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	PRB(Power Running Board)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RCM(Restraint Control Module)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	RETM(Rear Entertainment Module)																								
Ford	Explorer SportTrac	2006 MY	4.0L	2V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SYSTEM SEARCH																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PCM(Powertrain Control Module)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	TCM(Transmission Control Module)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	4X4(4x4 Control Module)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ABS(Anti-Lock Brake System)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Explorer SportTrac	2006 MY	4.6L	3V	ACM(Audio Control Module)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	DSM(Driver's Seat Module)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	EATC(Electronic Automatic Temperature Control)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	GEM(Generic Electronic Module)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	IC(Instrument Cluster)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	OCSM(Occupant Classification System Module)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PAM(Parking Aid Module)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	PRB(Power Running Board)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RCM(Restraint Control Module)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	RETM(Rear Entertainment Module)																								
Ford	Explorer SportTrac	2006 MY	4.6L	3V	SDARS(Satellite Digital Audio Receiver System)																								
Ford	E-Series	5.4L	2V	2004 ~	SYSTEM SEARCH																								
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																								
Ford	E-Series	5.4L	2V	2004 ~	PCM(PowerTrain Control Module)																								
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																								
Ford	E-Series	5.4L	2V	2004 ~	ABS(Anti-Lock Brake System)																								
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																								
Ford	E-Series	5.4L	2V	2004 ~	IC(Instrument Cluster)																								
Ford	E-Series	5.4L	2V	2004 ~	RAP(Remote Anti-Theft/Personality Module)																								
Ford	E-Series	5.4L	2V	2004 ~	RCM(Restraint Control Module)																								
Ford	E-Series	5.4L	2V	2004 ~	PAM(Parking Aid Module)																								
Ford	E-Series	5.4L	2V	2004 ~	VSM(Vehicle Security Module)																								
Ford	E-Series	5.4L	2V	2009 ~	SYSTEM SEARCH																								
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																								
Ford	E-Series	5.4L	2V	2009 ~	PCM(PowerTrain Control Module)																								
Ford	E-Series	5.4L	2V	2009 ~	ABS(Anti-Lock Brake System)																								
Ford	E-Series	5.4L	2V	2009 ~	ACM(Audio Control Module)																								
Ford	E-Series	5.4L	2V	2009 ~	APIM(Accessory Protocol Interface Module)																								
Ford	E-Series	5.4L	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	E-Series	5.4L	2V	2009 ~	GPSM(Global Positioning System Module)																								
Ford	E-Series	5.4L	2V	2009 ~	IPC(Instrument Panel Control Module)																								
Ford	E-Series	5.4L	2V	2009 ~	PAM(Parking Aid Module)																								
Ford	E-Series	5.4L	2V	2009 ~	RCM(Restraint Control Module)																								
Ford	E-Series	5.4L	2V	2009 ~	SDARS(Satellite Digital Audio Receiver System)																								
Ford	E-Series	5.4L	2V	2009 ~	TBC(Trailer Brake Control Module)																								
Ford	E-Series	5.4L	2V	2009 ~	TCM(Transmission Control Module)																								
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(Powertrain Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM(Transfer Case Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB(Power Running Board)																									
Ford	F150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	F150	3.7L(BETA)	TiVCT	SYSTEM SEARCH																									
Ford	F150	3.7L(BETA)	TiVCT	PCM(Powertrain Control Module)																									
Ford	F150	3.7L(BETA)	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	F150	3.7L(BETA)	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	F150	3.7L(BETA)	TiVCT	BCM(Body Control Module)																									
Ford	F150	3.7L(BETA)	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	F150	3.7L(BETA)	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	F150	3.7L(BETA)	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	F150	3.7L(BETA)	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	F150	3.7L(BETA)	TiVCT	PAM(Parking Aid Module)																									
Ford	F150	3.7L(BETA)	TiVCT	PSCM(Power Steering Control Module)																									
Ford	F150	3.7L(BETA)	TiVCT	RCM(Restraint Control Module)																									
Ford	F150	3.7L(BETA)	TiVCT	SCCM(Steering Column Control Module)																									
Ford	F150	3.7L(BETA)	TiVCT	TBC(Trailer Brake Control Module)																									
Ford	F150	3.7L(BETA)	TiVCT	TCCM(Transfer Case Control Module)																									
Ford	F150	3.7L(BETA)	TiVCT	ACM(Audio Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	F150	3.7L(BETA)	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F150	3.7L(BETA)	TiVCT	DSM(Driver's Seat Module)																									
Ford	F150	3.7L(BETA)	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	F150	3.7L(BETA)	TiVCT	FDIM(Front Display Interface Module)																									
Ford	F150	3.7L(BETA)	TiVCT	GPSM(Global Positioning System Module)																									
Ford	F150	3.7L(BETA)	TiVCT	PRB(Power Running Board)																									
Ford	F150	3.7L(BETA)	TiVCT	RTM(Radio Transceiver Module)																									
Ford	F150	4.6L(BETA)	2V	2009 ~	SYSTEM SEARCH																								
Ford	F150	4.6L(BETA)	2V	2009 ~	PCM(Powertrain Control Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	ABS(Anti-Lock Brake System)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	ACM(Audio Control Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	APIM(Accessory Protocol Interface Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	DSM(Driver's Seat Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	DSP(Digital Signal Processing Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	FCIM(Front Controls Interface Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	FDIM(Front Display Interface Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	GPSM(Global Positioning System Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	IC(Instrument Cluster)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	ILCM(Interior Lighting Control Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	OCSM(Occupant Classification System Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	PAM(Parking Aid Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	PRB(Power Running Board)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	RCM(Restraint Control Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	TBC(Trailer Brake Control Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	TCCM(Transfer Case Control Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	TCM(Transmission Control Module)																								
Ford	F150	4.6L(BETA)	2V	2009 ~	TPM(Tire Pressure Monitor)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	SYSTEM SEARCH																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PCM(Powertrain Control Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	4X4(4x4 Control Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	ABS(Anti-Lock Brake System)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RIM(Remote Immobilizer Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	GEM(Generic Electronic Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	DSM(Driver's Seat Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	IC(Instrument Cluster)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	PAM(Parking Aid Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RCM(Restraint Control Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	VSM(Vehicle Security Module)																								
Ford	F150	4.6L(BETA)	2V	2004 ~ 2008	RETM(Rear Entertainment Module)																								
Ford	F150	4.6L(BETA)	3V	SYSTEM SEARCH																									
Ford	F150	4.6L(BETA)	3V	PCM(Powertrain Control Module)																									
Ford	F150	4.6L(BETA)	3V	ABS(Anti-Lock Brake System)																									
Ford	F150	4.6L(BETA)	3V	ACM(Audio Control Module)																									
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	3V	APIM(Accessory Protocol Interface Module)																									
Ford	F150	4.6L(BETA)	3V	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F150	4.6L(BETA)	3V	DSM(Driver's Seat Module)																									
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	3V	DSP(Digital Signal Processing Module)																									
Ford	F150	4.6L(BETA)	3V	FCIM(Front Controls Interface Module)																									
Ford	F150	4.6L(BETA)	3V	FDIM(Front Display Interface Module)																									
Ford	F150	4.6L(BETA)	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	4.6L(BETA)	3V	GPSM(Global Positioning System Module)																									
Ford	F150	4.6L(BETA)	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	4.6L(BETA)	3V	IC(Instrument Cluster)																									
Ford	F150	4.6L(BETA)	3V	ILCM(Interior Lighting Control Module)																									
Ford	F150	4.6L(BETA)	3V	OCSM(Occupant Classification System Module)																									
Ford	F150	4.6L(BETA)	3V	PAM(Parking Aid Module)																									
Ford	F150	4.6L(BETA)	3V	PRB(Power Running Board)																									
Ford	F150	4.6L(BETA)	3V	RCM(Restraint Control Module)																									
Ford	F150	4.6L(BETA)	3V	TBC(Trailer Brake Control Module)																									
Ford	F150	4.6L(BETA)	3V	TCCM(Transfer Case Control Module)																									
Ford	F150	4.6L(BETA)	3V	TCM(Transmission Control Module)																									
Ford	F150	4.6L(BETA)	3V	TPM(Tire Pressure Monitor)																									
Ford	F150	5.0L	TiVCT	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	F150	5.0L	TiVCT	PCM(Powertrain Control Module)																									
Ford	F150	5.0L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	F150	5.0L	TiVCT	ACM(Audio Control Module)																									
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	F150	5.0L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	F150	5.0L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	F150	5.0L	TiVCT	DSM(Driver's Seat Module)																									
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	F150	5.0L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	F150	5.0L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	F150	5.0L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	F150	5.0L	TiVCT	FDIM(Front Display Interface Module)																									
Ford	F150	5.0L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	5.0L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	F150	5.0L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	5.0L	TiVCT	IC(Instrument Cluster)																									
Ford	F150	5.0L	TiVCT	ILCM(Interior Lighting Control Module)																									
Ford	F150	5.0L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																									
Ford	F150	5.0L	TiVCT	PAM(Parking Aid Module)																									
Ford	F150	5.0L	TiVCT	PRB(Power Running Board)																									
Ford	F150	5.0L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	F150	5.0L	TiVCT	RCM(Restraint Control Module)																									
Ford	F150	5.0L	TiVCT	RTM(Radio Transceiver Module)																									
Ford	F150	5.0L	TiVCT	SCCM(Steering Column Control Module)																									
Ford	F150	5.0L	TiVCT	TBC(Trailer Brake Control Module)																									
Ford	F150	5.0L	TiVCT	TCCM(Transfer Case Control Module)																									
Ford	F150	5.0L	TiVCT	TCM(Transmission Control Module)																									
Ford	F150	5.0L	TiVCT	TPM(Tire Pressure Monitor)																									
Ford	F150	5.4L	3V	2009 ~	SYSTEM SEARCH																								
Ford	F150	5.4L	3V	2009 ~	PCM(Powertrain Control Module)																								
Ford	F150	5.4L	3V	2009 ~	ABS(Anti-Lock Brake System)																								
Ford	F150	5.4L	3V	2009 ~	ACM(Audio Control Module)																								
Ford	F150	5.4L	3V	2009 ~	APIM(Accessory Protocol Interface Module)																								
Ford	F150	5.4L	3V	2009 ~	DCSM(Driver-Dual Climate Control Seat Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	F150	5.4L	3V	2009 ~	DSM(Driver's Seat Module)																								
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																								
Ford	F150	5.4L	3V	2009 ~	DSP(Digital Signal Processing Module)																								
Ford	F150	5.4L	3V	2009 ~	FCIM(Front Controls Interface Module)																								
Ford	F150	5.4L	3V	2009 ~	FDIM(Front Display Interface Module)																								
Ford	F150	5.4L	3V	2009 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	F150	5.4L	3V	2009 ~	GPSM(Global Positioning System Module)																								
Ford	F150	5.4L	3V	2009 ~	HVAC(Heating Ventilation Air Conditioning)																								
Ford	F150	5.4L	3V	2009 ~	IC(Instrument Cluster)																								
Ford	F150	5.4L	3V	2009 ~	ILCM(Interior Lighting Control Module)																								
Ford	F150	5.4L	3V	2009 ~	OCSM(Occupant Classification System Module)																								
Ford	F150	5.4L	3V	2009 ~	PAM(Parking Aid Module)																								
Ford	F150	5.4L	3V	2009 ~	PRB(Power Running Board)																								
Ford	F150	5.4L	3V	2009 ~	RCM(Restraint Control Module)																								
Ford	F150	5.4L	3V	2009 ~	TBC(Trailer Brake Control Module)																								
Ford	F150	5.4L	3V	2009 ~	TCCM(Transfer Case Control Module)																								
Ford	F150	5.4L	3V	2009 ~	TCM(Transmission Control Module)																								
Ford	F150	5.4L	3V	2009 ~	TPM(Tire Pressure Monitor)																								
Ford	F150	5.4L	3V	2004 ~ 2008	SYSTEM SEARCH																								
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																								
Ford	F150	5.4L	3V	2004 ~ 2008	PCM(Powertrain Control Module)																								
Ford	F150	5.4L	3V	2004 ~ 2008	4X4(4x4 Control Module)																								
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																								
Ford	F150	5.4L	3V	2004 ~ 2008	ABS(Anti-Lock Brake System)																								
Ford	F150	5.4L	3V	2004 ~ 2008	EATC(Electronic Automatic Temperature Control)																								
Ford	F150	5.4L	3V	2004 ~ 2008	RIM(Remote Immobilizer Module)																								
Ford	F150	5.4L	3V	2004 ~ 2008	GEM(Generic Electronic Module)																								
Ford	F150	5.4L	3V	2004 ~ 2008	DSM(Driver's Seat Module)																								
Ford	F150	5.4L	3V	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																								
Ford	F150	5.4L	3V	2004 ~ 2008	IC(Instrument Cluster)																								
Ford	F150	5.4L	3V	2004 ~ 2008	PAM(Parking Aid Module)																								
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																								
Ford	F150	5.4L	3V	2004 ~ 2008	RCM(Restraint Control Module)																								
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																								
Ford	F150	5.4L	3V	2004 ~ 2008	VSM(Vehicle Security Module)																								
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																								
Ford	F150	5.4L	3V	2004 ~ 2008	PATS(Passive Anti Theft System)																								
Ford	F150	6.2L(BETA)	2V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	F150	6.2L(BETA)	2V	PCM(Powertrain Control Module)																									
Ford	F150	6.2L(BETA)	2V	ABS(Anti-Lock Brake System)																									
Ford	F150	6.2L(BETA)	2V	ACM(Audio Control Module)																									
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																									
Ford	F150	6.2L(BETA)	2V	APIM(Accessory Protocol Interface Module)																									
Ford	F150	6.2L(BETA)	2V	DSM(Driver's Seat Module)																									
Ford	F150	6.2L(BETA)	2V	DSP(Digital Signal Processing Module)																									
Ford	F150	6.2L(BETA)	2V	FCIM(Front Controls Interface Module)																									
Ford	F150	6.2L(BETA)	2V	FCDIM(Front Control/Display Interface Module)																									
Ford	F150	6.2L(BETA)	2V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F150	6.2L(BETA)	2V	GPSM(Global Positioning System Module)																									
Ford	F150	6.2L(BETA)	2V	IC(Instrument Cluster)																									
Ford	F150	6.2L(BETA)	2V	ILCM(Interior Lighting Control Module)																									
Ford	F150	6.2L(BETA)	2V	OCSM(Occupant Classification System Module)																									
Ford	F150	6.2L(BETA)	2V	PAM(Parking Aid Module)																									
Ford	F150	6.2L(BETA)	2V	PRB(Power Running Board)																									
Ford	F150	6.2L(BETA)	2V	RCM(Restraint Control Module)																									
Ford	F150	6.2L(BETA)	2V	TBC(Trailer Brake Control Module)																									
Ford	F150	6.2L(BETA)	2V	TCCM(Transfer Case Control Module)																									
Ford	F150	6.2L(BETA)	2V	TCM(Transmission Control Module)																									
Ford	F150	6.2L(BETA)	2V	TPM(Tire Pressure Monitor)																									
Ford	F150	Other	2004 ~ 2008	SYSTEM SEARCH																									
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	Other	2004 ~ 2008	PCM(Powertrain Control Module)																									
Ford	F150	Other	2004 ~ 2008	4X4(4x4 Control Module)																									
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	Other	2004 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	F150	Other	2004 ~ 2008	RIM(Remote Immobilizer Module)																									
Ford	F150	Other	2004 ~ 2008	GEM(Generic Electronic Module)																									
Ford	F150	Other	2004 ~ 2008	DSM(Driver's Seat Module)																									
Ford	F150	Other	2004 ~ 2008	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F150	Other	2004 ~ 2008	IC(Instrument Cluster)																									
Ford	F150	Other	2004 ~ 2008	PAM(Parking Aid Module)																									
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	Other	2004 ~ 2008	RCM(Restraint Control Module)																									
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	Other	2004 ~ 2008	VSM(Vehicle Security Module)																									
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	F150	Other	2004 ~ 2008	PATS(Passive Anti Theft System)																									
Ford	F250	7.3L	SYSTEM SEARCH																										
Ford	F250	7.3L	PCM(PowerTrain Control Module)																										
Ford	F250	7.3L	ABS(Anti-Lock Brake System)																										
Ford	F250	7.3L	ECS(Electronic Crash Sensor)																										
Ford	F250	7.3L	GEM(Generic Electronic Module)																										
Ford	F250	6.2L	SYSTEM SEARCH																										
Ford	F250	6.2L	PCM(Powertrain Control Module)																										
Ford	F250	6.2L	ABS(Anti-Lock Brake System)																										
Ford	F250	6.2L	ACM(Audio Control Module)																										
Ford	F250	6.2L	APIM(Accessory Protocol Control Module)																										
Ford	F250	6.2L	BCMii(Body Control Module)																										
Ford	F250	6.2L	DCSM(Driver-Dual Climate Contol Seat Module)																										
Ford	F250	6.2L	DSM(Driver Seat Module)																										
Ford	F250	6.2L	GPSM(Global Positioning System Module)																										
Ford	F250	6.2L	HVAC(Heating Ventilation Air Conditioning)																										
Ford	F250	6.2L	IPC(Instrument Panel Control Module)																										
Ford	F250	6.2L	PAM(Parking Aid Module)																										
Ford	F250	6.2L	RCM(Restraint Control Module)																										
Ford	F250	6.2L	SCCM(Streering Colume Control Module)																										
Ford	F250	6.2L	TBC(Trailer Brake Control Module)																										
Ford	F250	6.2L	TCCM(Transfer Case Control Module)																										
Ford	F250	6.2L	TPM(Tire Pressure Monitor)																										
Ford	F250	6.0L	SYSTEM SEARCH																										
Ford	F250	6.0L	PCM(PowerTrain Control Module)																										
Ford	F250	6.0L	PCM(PowerTrain Control Module)																										
Ford	F250	6.0L	PCM(PowerTrain Control Module)																										
Ford	F250	6.0L	ABS(Anti-Lock Brake System)																										
Ford	F250	6.0L	GEM(Generic Electronic Module)																										
Ford	F250	6.0L	HEC(Hybrid Electrical Cluster)																										
Ford	F250	6.0L	OTC(Overhead Trip Computer)																										
Ford	F250	6.0L	PAM(Parking Aid Module)																										
Ford	F250	6.0L	PATS(Passive Anti Theft System)																										
Ford	F250	6.0L	RCM(Restraint Control Module)																										
Ford	F250	6.0L	TCM(Transmission Control Module)																										
Ford	F250	6.0L	TCM(Transmission Control Module)																										
Ford	F250	6.0L	TCM(Transmission Control Module)																										
Ford	F250	6.0L	VSM(Vehicle Security Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SYSTEM SEARCH																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM(PowerTrain Control Module)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4(4x4 Control Module)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS(Anti-Lock Brake System)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM(Audio Control Module)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM(Auxiliary Heater Control Module)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM(Accessory Protocol Interface Module)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM(Circuit Deactivation Ignition Module)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM(Driver's Seat Module)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GPSM(Global Positioning System Module)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC(Heating Ventilation Air Conditioning)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC(Instrument Cluster)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM(Parking Aid Module)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM(Restraint Control Module)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM(Rear Entertainment Module)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS(Satellite Digital Audio Receiver System)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC(Trailer Brake Control Module)																									
Ford	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM(Transmission Control Module)																									
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SYSTEM SEARCH																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PCM(PowerTrain Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCM(Transmission Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ABS(Anti-Lock Brake System)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	ACM(Audio Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	AHCM(Auxiliary Heater Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	APIM(Accessory Protocol Interface Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	BCM(Body Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	CDIM(Circuit Deactivation Ignition Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSM(Driver's Seat Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	DSP(Digital Signal Processing Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	FCIM(Front Controls Interface Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	GPSM(Global Positioning System Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HSWM(Heated Steering Wheel Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	HVAC(Heating Ventilation Air Conditioning)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	IPC(Instrument Panel Control Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	PAM(Parking Aid Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RCM(Restraint Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	RTM(Radio Transceiver Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	SCCM(Steering Column Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TBC(Trailer Brake Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TCCM(Transfer Case Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2013 ~	TRM(Trailer Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SYSTEM SEARCH																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PCM(PowerTrain Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ABS(Anti-Lock Brake System)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	ACM(Audio Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	AHCM(Auxiliary Heater Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	APIM(Accessory Protocol Interface Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	BCMii(Body Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	CDIM(Circuit Deactivation Ignition Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	DSM(Driver's Seat Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	GPSM(Global Positioning System Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	HVAC(Heating Ventilation Air Conditioning)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	IPC(Instrument Panel Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	PAM(Parking Aid Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	RCM(Restraint Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SCCM(Steering Column Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	SDARS(Satellite Digital Audio Receiver System)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TBC(Trailer Brake Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCCM(Transfer Case Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TCM(Transmission Control Module)																								
Ford	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	~ 2012	TPM(Tire Pressure Monitor)																								
Ford	Fiesta	1.4L	DURATEC 16V	SYSTEM SEARCH																									
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	TCM(Transmission Control Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																									
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Fiesta	1.4L	DURATEC 16V	ABS(Anti-Lock Brake System)																									
Ford	Fiesta	1.4L	DURATEC 16V	PSCM(Power Steering Control Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	RCM(Restraint Control Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	IPC(Instrument Panel Control Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	GEM(Generic Electronic Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	BCMii(Body Control Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	FCDIM(Front Control/Display Interface Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	SRM(Speech Recognition Module)																									
Ford	Fiesta	1.4L	DURATEC 16V	ACM(Audio Control Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																									
Ford	Fiesta	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																									
Ford	Fiesta	1.6L	DURATEC	SYSTEM SEARCH																									
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.6L	DURATEC	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																									
Ford	Fiesta	1.6L	DURATEC	TCM(Transmission Control Module)																									
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																									
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Fiesta	1.6L	DURATEC	ABS(Anti-Lock Brake System)																									
Ford	Fiesta	1.6L	DURATEC	PSCM(Power Steering Control Module)																									
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																									
Ford	Fiesta	1.6L	DURATEC	RCM(Restraint Control Module)																									
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																									
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																									
Ford	Fiesta	1.6L	DURATEC	IPC(Instrument Panel Control Module)																									
Ford	Fiesta	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																									
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																									
Ford	Fiesta	1.6L	DURATEC	GEM(Generic Electronic Module)																									
Ford	Fiesta	1.6L	DURATEC	BCMii(Body Control Module)																									
Ford	Fiesta	1.6L	DURATEC	FCDIM(Front Control/Display Interface Module)																									
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																									
Ford	Fiesta	1.6L	DURATEC	SRM(Speech Recognition Module)																									
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																									
Ford	Fiesta	1.6L	DURATEC	ACM(Audio Control Module)																									
Ford	Fiesta	1.6L	TiVCT	SYSTEM SEARCH																									
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.6L	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.6L	TiVCT	TCM(Transmission Control Module)																									
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Fiesta	1.6L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																									
Ford	Fiesta	1.6L	TiVCT	ACM(Audio Control Module)																									
Ford	Fiesta	1.6L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Fiesta	1.6L	TiVCT	BCM(Body Control Module)																									
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Fiesta	1.6L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Fiesta	1.6L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Fiesta	1.6L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Fiesta	1.6L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Fiesta	1.6L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Fiesta	1.6L	TiVCT	RCM(Restraint Control Module)																									
Ford	Fiesta	1.6L	TiVCT	RFA(Remote Function Actuator)																									
Ford	Fiesta	1.6L	TiVCT	VSM(Vehicle Security Module)																									
Ford	Fiesta	1.6L	Zetec Rocam	SYSTEM SEARCH																									
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Fiesta	1.6L	Zetec Rocam	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.6L	Zetec Rocam	ABS(Anti-Lock Brake System)																									
Ford	Fiesta	1.6L	Zetec Rocam	IC(Instrument Cluster)																									
Ford	Fiesta	1.6L	Zetec Rocam	RCM(Restraint Control Module)																									
Ford	Fiesta	1.6L	Zetec Rocam	RKE(Remote Keyless Entry)																									
Ford	Fiesta	1.6L	Zetec Rocam	TCM(Transmission Control Module)																									
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	SYSTEM SEARCH																									
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	PCM(PowerTrain Control Module)																									
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ABS(Anti-Lock Brake System)																									
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	ECS(Electronic Crash Sensor)																									
Ford	Fiesta	1.8L	ENDURA-DE DIESEL	HEC(Hybrid Electrical Cluster)																									
Ford	Fiesta	2.0L	SYSTEM SEARCH																										
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																										
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																										
Ford	Fiesta	2.0L	PCM(PowerTrain Control Module)																										
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	2.0L	ABS(Anti-Lock Brake System)																										
Ford	Fiesta	2.0L	ACM(Audio Control Module)																										
Ford	Fiesta	2.0L	EATC(Electronic Automatic Temperature Control)																										
Ford	Fiesta	2.0L	GEM(Generic Electronic Module)																										
Ford	Fiesta	2.0L	IC(Instrument Cluster)																										
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																										
Ford	Fiesta	2.0L	SRM(Speech Recognition Module)																										
Ford	Fiesta	2.0L	RCM(Restraint Control Module)																										
Ford	Fiesta	2.0L	PATS(Passive Anti Theft System)-BETA																										
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																									
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	PCM(Powertrain Control Module)																									
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																									
Ford	Figo	1.4L	DV4 Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																									
Ford	Focus	1.6L	ZETEC ROCAM	SYSTEM SEARCH																									
Ford	Focus	1.6L	ZETEC ROCAM	PCM(PowerTrain Control Module)																									
Ford	Focus	1.6L	ZETEC ROCAM	ABS(Anti-Lock Brake System)																									
Ford	Focus	1.6L	ZETEC ROCAM	EATC(Electronic Automatic Temperature Control)																									
Ford	Focus	1.6L	ZETEC ROCAM	GEM(Generic Electronic Module)																									
Ford	Focus	1.6L	ZETEC ROCAM	HCM(Headlamp Control Module)																									
Ford	Focus	1.6L	ZETEC ROCAM	RCM(Restraint Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Focus	1.6L	ZETEC ROCAM	MC(Message Center)																									
Ford	Focus	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																									
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Focus	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Focus	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	CSM(Central Security Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																									
Ford	Focus	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																									
Ford	Focus	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																									
Ford	Focus	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																									
Ford	Focus	1.6L	DURATEC-HE/I4	EPS(Electronic power steering)																									
Ford	Focus	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	NAV(Navigation System)																									
Ford	Focus	1.6L	DURATEC-HE/I4	HEC(Hybrid Electrical Cluster)																									
Ford	Focus	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																									
Ford	Focus	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																									
Ford	Focus	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																									
Ford	Focus	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																									
Ford	Focus	1.6L	DURATEC-HE/I4	SRM(Speech recognition module)																									
Ford	Focus	1.6L	DURATEC-HE/I4	MC(Message Center)																									
Ford	Focus	1.6L	DURATEC VCT	SYSTEM SEARCH																									
Ford	Focus	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																									
Ford	Focus	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																									
Ford	Focus	1.6L	DURATEC VCT	ACM(Audio Control Module)																									
Ford	Focus	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																									
Ford	Focus	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Focus	1.6L	DURATEC VCT	BCMii(Body Control Module)																									
Ford	Focus	1.6L	DURATEC VCT	DDM(Driver's Door Module)																									
Ford	Focus	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																									
Ford	Focus	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Focus	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																									
Ford	Focus	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Focus	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																									
Ford	Focus	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																									
Ford	Focus	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																									
Ford	Focus	1.6L	DURATEC VCT	PAM(Parking Aid Module)																									
Ford	Focus	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																									
Ford	Focus	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																									
Ford	Focus	1.6L	DURATEC VCT	RCM(Restraint Control Module)																									
Ford	Focus	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																									
Ford	Focus	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																									
Ford	Focus	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																									
Ford	Focus	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																									
Ford	Focus	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Focus	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Focus	1.6L	DURATEC VCT	TRM(Trailer Module)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D_DCU(Driver Door Control Unit)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic power steering)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																									
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Focus	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																									
Ford	Focus	1.8L	DURATEC HE/I4	SYSTEM SEARCH																									
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	PCM(PowerTrain Control Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Focus	1.8L	DURATEC HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Focus	1.8L	DURATEC HE/I4	ACM(Audio control module)																									
Ford	Focus	1.8L	DURATEC HE/I4	CDP(Compact Disc Player)																									
Ford	Focus	1.8L	DURATEC HE/I4	CSM(Central Security Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	D_DCU(Driver Door Control Unit)																									
Ford	Focus	1.8L	DURATEC HE/I4	EATC(Electronic Automatic Temperature Control)																									
Ford	Focus	1.8L	DURATEC HE/I4	EPS(Electronic power steering)																									
Ford	Focus	1.8L	DURATEC HE/I4	GDM(Generic Display Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	FFH(Fuel Fired Coolant Heating Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	GEM(Generic Electronic Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	IC(Instrument cluster)																									
Ford	Focus	1.8L	DURATEC HE/I4	NAV(Navigation System)																									
Ford	Focus	1.8L	DURATEC HE/I4	PAM(Parking Aid Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	PDM(Passenger's Door Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	RETM(Rear Entertainment Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	RKE(Remote Keyless Entry)																									
Ford	Focus	1.8L	DURATEC HE/I4	SRM(Speech recognition module)																									
Ford	Focus	1.8L	DURATEC HE/I4	HCM(Headlamp Control Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	HEC(Hybrid Electrical Cluster)																									
Ford	Focus	1.8L	DURATEC HE/I4	MC(Message Center)																									
Ford	Focus	1.8L	DURATEC HE/I4	RCM(Restraint Control Module)																									
Ford	Focus	1.8L	DURATEC HE/I4	TCM(Transmission Control Module)																									
Ford	Focus	2.0L DURATEC HE/I4	~2007	SYSTEM SEARCH																									
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																									
Ford	Focus	2.0L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																									
Ford	Focus	2.0L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																									
Ford	Focus	2.0L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																									
Ford	Focus	2.0L DURATEC HE/I4	~2007	IC(Instrument cluster)																									
Ford	Focus	2.0L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	PCM(PowerTrain Control Module)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	ABS(Anti-Lock Brake System)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	ACM(Audio control module)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	APIM(Accessory Protocol Interface Module)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	FCIM(Front Controls Interface Module)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	FDIM(Front Display Interface Module)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	GPSM(Global Positioning System Module)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	IC(Instrument cluster)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	OCSM(Occupant Classification System Module)																									
Ford	Focus	2.0L DURATEC HE/I4	2008~	RCM(Restraint Control Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SYSTEM SEARCH																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PCM(PowerTrain Control Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TCM(Transmission control module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ABS(Anti-Lock Brake System)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	ACM(Audio control module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CDP(Compact Disc Player)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	CSM(Central Security Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	D_DCU(Driver Door Control Unit)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EATC(Electronic Automatic Temperature Control)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	EPS(Electronic power steering)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GDM(Generic Display Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	FFH(Fuel Fired Coolant Heating Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	GEM(Generic Electronic Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HEC(Hybrid Electrical Cluster)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	IC(Instrument cluster)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	MC(Message Center)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	NAV(Navigation System)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PAM(Parking Aid Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	PDM(Passenger's Door Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RETM(Rear Entertainment Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RKE(Remote Keyless Entry)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	TBM(Tracking And Blocking Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RL_DCU(Rear Left Door Control Unit)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RR_DCU(Rear Right Door Control Unit)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	SRM(Speech recognition module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	HCM(Headlamp Control Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																									
Ford	Focus	2.0L DURATEC	2003 ~ 2007	RCM(Restraint Control Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SYSTEM SEARCH																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PCM(PowerTrain Control Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ABS(Anti-Lock Brake System)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	ACM(Audio Control Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	APIM(Accessory Protocol Interface Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	BCM(Body Control Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DDM(Driver's Door Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	DSP(Digital Signal Processing Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCIM(Front Controls Interface Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	FCDIM(Front Control/Display Interface Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	GPSM(Global Positioning System Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	IPC(Instrument Panel Control Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	OCSM(Occupant Classification System Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PAM(Parking Aid Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PDM(Passenger's Door Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	PSCM(Power Steering Control Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RCM(Restraint Control Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	RFA(Remote Function Actuator)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	SASM(Steering Angle Sensor Module)																									
Ford	Focus	2.0L GASOLINE DIRECT INJECTION	2012 ~	TCM(Transmission Control Module)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	SYSTEM SEARCH																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PCM(PowerTrain Control Module)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CDP(Compact Disc Player)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	CMR(Camera Module Rear)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Focus	2.0L DIESEL	2003 ~ 2008	D_DCU(Driver Door Control Unit)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EATC(Electronic Automatic Temperature Control)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	EPS(Electronic power steering)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FACM(Fuel Additive Control Module)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	FFH(Fuel Fired Coolant Heating Module)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	GEM(Generic Electronic Module)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	HCM(Headlamp Control Module)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	IC(Instrument cluster)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PDM(Passenger's Door Module)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	PAM(Parking Aid Module)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RCM(Restraint Control Module)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RETM(Rear Entertainment Module)																									
Ford	Focus	2.0L DIESEL	2003 ~ 2008	RKE(Remote Keyless Entry)																									
Ford	Focus	2.3L DURATEC HE/I4	~2007	SYSTEM SEARCH																									
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																									
Ford	Focus	2.3L DURATEC HE/I4	~2007	PCM(PowerTrain Control Module)																									
Ford	Focus	2.3L DURATEC HE/I4	~2007	ABS(Anti-Lock Brake System)																									
Ford	Focus	2.3L DURATEC HE/I4	~2007	GEM(Generic Electronic Module)																									
Ford	Focus	2.3L DURATEC HE/I4	~2007	IC(Instrument cluster)																									
Ford	Focus	2.3L DURATEC HE/I4	~2007	RCM(Restraint Control Module)																									
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	SYSTEM SEARCH																									
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PCM(PowerTrain Control Module)																									
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	TCM(Transmission control module)																									
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ABS(Anti-Lock Brake System)																									
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	EPS(Electronic power steering)																									
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	RCM(Restraint Control Module)																									
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	GEM(Generic Electronic Module)																									
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	IC(Instrument cluster)																									
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	DDM(Driver's Door Module)																									
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	PDM(Passenger's Door Module)																									
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	MC(Message Center)																									
Ford	Focus	2.5L GASOLINE	2003 ~ 2008	ACM(Audio control module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CDP(Compact Disc Player)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	D DCU(Driver Door Control Unit)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	EPS(Electronic Power Steering)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FACM(Fuel Additive Control Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RETM(Rear Entertainment Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RKE(Remote Keyless Entry)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-A(Image Processing Module A)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPM-B(Image Processing Module B)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	RGTM(Rear Gate/Trunk Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Focus C-MAX	1.6L	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)-BETA																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SYSTEM SEARCH																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CDP(Compact Disc Player)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	CMR(Camera Module Rear)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	EPS(Electronic Power Steering)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GEM(Generic Electronic Module)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	HCM(Headlamp Control Module)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	IC(Instrument Cluster)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PAM(Parking Aid Module)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	PDM(Passenger's Door Module)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	GDM(Generic Display Module)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	NAV(Navigation System)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RL_DCU(Rear Left Door Control Unit)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	RR_DCU(Rear Right Door Control Unit)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	SRM(Speech Recognition Module)																									
Ford	Focus C-MAX	1.6L	DURATEC-HE/I4	TCM(Transmission Control Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	SYSTEM SEARCH																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	PCM(PowerTrain Control Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	ABS(Anti-Lock Brake System)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	ACM(Audio Control Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	AHCM(Auxiliary Heater Control Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	APIM(Accessory Protocol Interface Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	BCMii(Body Control Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	DDM(Driver's Door Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	FDSM(Front Distance Sensing Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	HCM(Headlamp Control Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-A(Image Processing Module A)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPM-B(Image Processing Module B)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	IPC(Instrument Panel Control Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	PAM(Parking Aid Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Focus C-MAX	1.6L	DURATEC VCT	PDM(Passenger's Door Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	PSCM(Power Steering Control Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	RCM(Restraint Control Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	RFA(Remote Function Actuator)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	RGTM(Rear Gate/Trunk Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	SASM(Steering Angle Sensor Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	SRM(Speech Recognition Module)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Focus C-MAX	1.6L	DURATEC VCT	TRM(Trailer Module)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SYSTEM SEARCH																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CMR(Camera Module Rear)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	CDP(Compact Disc Player)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	EPS(Electronic Power Steering)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GDM(Generic Display Module)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	GEM(Generic Electronic Module)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	HCM(Headlamp Control Module)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	IC(Instrument Cluster)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	NAV(Navigation System)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PAM(Parking Aid Module)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	PDM(Passenger's Door Module)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																									
Ford	Focus C-MAX	1.8L	DURATEC-HE/I4	SRM(Speech Recognition Module)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SYSTEM SEARCH																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CDP(Compact Disc Player)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	CMR(Camera Module Rear)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	D_DCU(Driver Door Control Unit)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EATC(Electronic Automatic Temperature Control)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPB(Electronic Parking Brake)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	EPS(Electronic Power Steering)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	FFH(Fuel Fired Coolant Heating Module)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GDM(Generic Display Module)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	GEM(Generic Electronic Module)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	HCM(Headlamp Control Module)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	IC(Instrument Cluster)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	NAV(Navigation System)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PAM(Parking Aid Module)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	PDM(Passenger's Door Module)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RETM(Rear Entertainment Module)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	RKE(Remote Keyless Entry)																									
Ford	Focus C-MAX	2.0L	DURATEC-HE/I4	SRM(Speech Recognition Module)																									
Ford	Flex	3.5L	4V	SYSTEM SEARCH																									
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																									
Ford	Flex	3.5L	4V	PCM(PowerTrain Control Module)																									
Ford	Flex	3.5L	4V	4X4(4x4 Control Module)																									
Ford	Flex	3.5L	4V	ABS(Anti-Lock Brake System)																									
Ford	Flex	3.5L	4V	ACM(Audio control module)																									
Ford	Flex	3.5L	4V	APIM(Accessory Protocol Interface Module)																									
Ford	Flex	3.5L	4V	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Flex	3.5L	4V	DDM(Driver's Door Module)																									
Ford	Flex	3.5L	4V	DSM(Driver's Seat Module)																									
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																									
Ford	Flex	3.5L	4V	DSP(Digital Signal Processing Module)																									
Ford	Flex	3.5L	4V	FCIM(Front Controls Interface Module)																									
Ford	Flex	3.5L	4V	FDIM(Front Display Interface Module)																									
Ford	Flex	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Flex	3.5L	4V	GPSM(Global Positioning System Module)																									
Ford	Flex	3.5L	4V	HCM(Headlamp Control Module)																									
Ford	Flex	3.5L	4V	HCM-2(Headlamp Control Module2)																									
Ford	Flex	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Flex	3.5L	4V	IC(Instrument cluster)																									
Ford	Flex	3.5L	4V	ILCM(Interior Lighting Control Module)																									
Ford	Flex	3.5L	4V	LTM(Liftgate/Trunk Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Flex	3.5L	4V	OCSM(Occupant Classification System Module)																									
Ford	Flex	3.5L	4V	PAM(Parking Aid Module)																									
Ford	Flex	3.5L	4V	PSCM(Power Steering Control Module)																									
Ford	Flex	3.5L	4V	RCM(Restraint Control Module)																									
Ford	Flex	3.5L	4V	RETM(Rear Entertainment Module)																									
Ford	Flex	3.5L	4V	SASM(Steering Angle Sensor Module)																									
Ford	Flex	3.5L	4V	Factory Keyless Entry Code																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4(4x4 Control Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio control module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM(Front Display Interface Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2(Headlamp Control Module2)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC(Instrument cluster)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM(Interior Lighting Control Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM(Liftgate/Trunk Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RETM(Rear Entertainment Module)																									
Ford	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																									
Ford	Flex	3.5L	TiVCT	SYSTEM SEARCH																									
Ford	Flex	3.5L	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Flex	3.5L	TiVCT	4X4(4x4 Control Module)																									
Ford	Flex	3.5L	TiVCT	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Flex	3.5L	TiVCT	ACM(Audio control module)																									
Ford	Flex	3.5L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Flex	3.5L	TiVCT	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Flex	3.5L	TiVCT	DDM(Driver's Door Module)																									
Ford	Flex	3.5L	TiVCT	DSM(Driver's Seat Module)																									
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Flex	3.5L	TiVCT	DSP(Digital Signal Processing Module)																									
Ford	Flex	3.5L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Flex	3.5L	TiVCT	FDIM(Front Display Interface Module)																									
Ford	Flex	3.5L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Flex	3.5L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Flex	3.5L	TiVCT	HCM(Headlamp Control Module)																									
Ford	Flex	3.5L	TiVCT	HCM-2(Headlamp Control Module2)																									
Ford	Flex	3.5L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Flex	3.5L	TiVCT	IC(Instrument cluster)																									
Ford	Flex	3.5L	TiVCT	ILCM(Interior Lighting Control Module)																									
Ford	Flex	3.5L	TiVCT	LTM(Liftgate/Trunk Module)																									
Ford	Flex	3.5L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Flex	3.5L	TiVCT	PAM(Parking Aid Module)																									
Ford	Flex	3.5L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Flex	3.5L	TiVCT	RCM(Restraint Control Module)																									
Ford	Flex	3.5L	TiVCT	RETM(Rear Entertainment Module)																									
Ford	Flex	3.5L	TiVCT	SASM(Steering Angle Sensor Module)																									
Ford	FreestarMonterey	3.9L	SYSTEM SEARCH																										
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																										
Ford	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																										
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																										
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																										
Ford	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																										
Ford	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																										
Ford	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																										
Ford	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																										
Ford	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																										
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																										
Ford	FreestarMonterey	3.9L	IC(Instrument Cluster)																										
Ford	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																										
Ford	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																										
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																										
Ford	FreestarMonterey	3.9L	RCM(Restraint Control Module)																										
Ford	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																										
Ford	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																										
Ford	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																										
Ford	FreestarMonterey	4.2L	SYSTEM SEARCH																										
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																										
Ford	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																										
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																										
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																										
Ford	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																										
Ford	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																										
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																										
Ford	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																										
Ford	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																										
Ford	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																										
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																										
Ford	FreestarMonterey	4.2L	IC(Instrument Cluster)																										
Ford	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																										
Ford	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																										
Ford	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																										
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																										
Ford	FreestarMonterey	4.2L	RCM(Restraint Control Module)																										
Ford	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																										
Ford	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																										
Ford	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																										
Ford	Freestyle	3.0L	4V	SYSTEM SEARCH																									
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																									
Ford	Freestyle	3.0L	4V	PCM(PowerTrain Control Module)																									
Ford	Freestyle	3.0L	4V	4X4(4x4 Control Module)																									
Ford	Freestyle	3.0L	4V	ABS(Anti-Lock Brake System)																									
Ford	Freestyle	3.0L	4V	ACM(Audio Control Module)																									
Ford	Freestyle	3.0L	4V	DSM(Driver's Seat Module)																									
Ford	Freestyle	3.0L	4V	EATC(Electronic Automatic Temperature Control)																									
Ford	Freestyle	3.0L	4V	GEM(Generic Electronic Module)																									
Ford	Freestyle	3.0L	4V	IC(Instrument Cluster)																									
Ford	Freestyle	3.0L	4V	PAM(Parking Aid Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Freestyle	3.0L	4V	RCM(Restraint Control Module)																									
Ford	Freestyle	3.0L	4V	TCM(Transmission Control Module)																									
Ford	Five Hundred	3.0L	4V	SYSTEM SEARCH																									
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																									
Ford	Five Hundred	3.0L	4V	PCM(PowerTrain Control Module)																									
Ford	Five Hundred	3.0L	4V	4X4(4x4 Control Module)																									
Ford	Five Hundred	3.0L	4V	ABS(Anti-Lock Brake System)																									
Ford	Five Hundred	3.0L	4V	ACM(Audio Control Module)																									
Ford	Five Hundred	3.0L	4V	DSM(Driver's Seat Module)																									
Ford	Five Hundred	3.0L	4V	EATC(Electronic Automatic Temperature Control)																									
Ford	Five Hundred	3.0L	4V	GEM(Generic Electronic Module)																									
Ford	Five Hundred	3.0L	4V	IC(Instrument Cluster)																									
Ford	Five Hundred	3.0L	4V	PAM(Parking Aid Module)																									
Ford	Five Hundred	3.0L	4V	RCM(Restraint Control Module)																									
Ford	Five Hundred	3.0L	4V	TCM(Transmission Control Module)																									
Ford	Ford GT	5.4L	4V	SYSTEM SEARCH																									
Ford	Ford GT	5.4L	4V	PCM(Powertrain Control Module)																									
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																									
Ford	Ford GT	5.4L	4V	ABS(Anti-Lock Brake System)																									
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																									
Ford	Ford GT	5.4L	4V	GEM(Generic Electronic Module)																									
Ford	Ford GT	5.4L	4V	IC(Instrument Cluster)																									
Ford	Ford GT	5.4L	4V	PATS(Passive Anti Theft System)																									
Ford	Ford GT	5.4L	4V	RCM(Restraint Control Module)																									
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																									
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																									
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																									
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission control module)																									
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument cluster)																									
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio control module)																									
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	EATC(Electronic Automatic Temperature Control)																									
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																									
Ford	Fusion	1.4L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																									
Ford	Fusion	1.6L	DURATEC	SYSTEM SEARCH																									
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																									
Ford	Fusion	1.6L	DURATEC	PCM(PowerTrain Control Module)																									
Ford	Fusion	1.6L	DURATEC	TCM(Transmission control module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Fusion	1.6L	DURATEC	ABS(Anti-Lock Brake System)																									
Ford	Fusion	1.6L	DURATEC	IC(Instrument cluster)																									
Ford	Fusion	1.6L	DURATEC	ACM(Audio control module)																									
Ford	Fusion	1.6L	DURATEC	EATC(Electronic Automatic Temperature Control)																									
Ford	Fusion	1.6L	DURATEC	GEM(Generic Electronic Module)																									
Ford	Fusion	1.6L	DURATEC	SRM(Speech Recognition Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii(Body Control Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SYSTEM SEARCH																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	ACM(Audio Control Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BCM(Body Control Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	C-CM(Cruise Control Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DDM(Driver's Door Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSM(Driver's Seat Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GFM(Generic Function Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	GWM(Gateway Module A)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	HUD(Head Up Display)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PAM(Parking Aid Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PDM(Passenger's Door Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RCM(Restraint Control Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	SOBDM(Secondary OBD Control Module A)																									
Ford	Fusion	2.0L	Plug-in Hybrid Electric Vehicle	TCU(Telematic Control Unit Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																									
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	PAM(Parking Aid Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Fusion	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																									
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Fusion	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Fusion	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																									
Ford	Fusion	2.5L	IVCT	SYSTEM SEARCH																									
Ford	Fusion	2.5L	IVCT	PCM(PowerTrain Control Module)																									
Ford	Fusion	2.5L	IVCT	ABS(Anti-Lock Brake System)																									
Ford	Fusion	2.5L	IVCT	ACM(Audio Control Module)																									
Ford	Fusion	2.5L	IVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Fusion	2.5L	IVCT	BCM(Body Control Module)																									
Ford	Fusion	2.5L	IVCT	C-CM(Cruise Control Module)																									
Ford	Fusion	2.5L	IVCT	DACM-C(Digital Audio Control Module C)																									
Ford	Fusion	2.5L	IVCT	DDM(Driver's Door Module)																									
Ford	Fusion	2.5L	IVCT	DSM(Driver's Seat Module)																									
Ford	Fusion	2.5L	IVCT	DSP(Digital Signal Processing Module)																									
Ford	Fusion	2.5L	IVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Fusion	2.5L	IVCT	FCIM(Front Controls Interface Module)																									
Ford	Fusion	2.5L	IVCT	GPSM(Global Positioning System Module)																									
Ford	Fusion	2.5L	IVCT	GWM(Gateway Module A)																									
Ford	Fusion	2.5L	IVCT	HUD(Head Up Display)																									
Ford	Fusion	2.5L	IVCT	IPC(Instrument Panel Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Fusion	2.5L	IVCT	IPM-A(Image Processing Module A)																									
Ford	Fusion	2.5L	IVCT	OCSM(Occupant Classification System Module)																									
Ford	Fusion	2.5L	IVCT	PAM(Parking Aid Module)																									
Ford	Fusion	2.5L	IVCT	PDM(Passenger's Door Module)																									
Ford	Fusion	2.5L	IVCT	PSCM(Power Steering Control Module)																									
Ford	Fusion	2.5L	IVCT	RACM(Rear Audio Control Module)																									
Ford	Fusion	2.5L	IVCT	RCM(Restraint Control Module)																									
Ford	Fusion	2.5L	IVCT	RTM(Radio Transceiver Module)																									
Ford	Fusion	2.5L	IVCT	SCCM(Steering Column Control Module)																									
Ford	Fusion	2.5L	IVCT	SCM-E(Seat Control Module E)																									
Ford	Fusion	2.5L	IVCT	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Fusion	2.5L	IVCT	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Fusion	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																									
Ford	Fusion	3.0L	4V	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																									
Ford	Fusion	3.0L	4V	PCM(PowerTrain Control Module)																									
Ford	Fusion	3.0L	4V	4X4(4x4 Control Module)																									
Ford	Fusion	3.0L	4V	ABS(Anti-Lock Brake System)																									
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																									
Ford	Fusion	3.0L	4V	ACM(Audio Control Module)																									
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																									
Ford	Fusion	3.0L	4V	APIM(Accessory Protocol Interface Module)																									
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																									
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																									
Ford	Fusion	3.0L	4V	FCIM(Front Controls Interface Module)																									
Ford	Fusion	3.0L	4V	FDIM(Front Display Interface Module)																									
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Fusion	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Fusion	3.0L	4V	GPSM(Global Positioning System Module)																									
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Fusion	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																									
Ford	Fusion	3.0L	4V	IPC(Instrument Panel Control Module)																									
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																									
Ford	Fusion	3.0L	4V	OCSM(Occupant Classification System Module)																									
Ford	Fusion	3.0L	4V	PAM(Parking Aid Module)																									
Ford	Fusion	3.0L	4V	PSCM(Power Steering Control Module)																									
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																									
Ford	Fusion	3.0L	4V	RCM(Restraint Control Module)																									
Ford	Fusion	3.0L	4V	TCM(Transmission Control Module)																									
Ford	Fusion	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Fusion	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Fusion	3.0L	4V	TBM(Tracking And Blocking Module)																									
Ford	Fusion	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Fusion	3.0L	4V	PATS(Passive Anti Theft System)																									
Ford	Fusion	3.5L	4V	SYSTEM SEARCH																									
Ford	Fusion	3.5L	4V	PCM(PowerTrain Control Module)																									
Ford	Fusion	3.5L	4V	TCM(Transmission Control Module)																									
Ford	Fusion	3.5L	4V	4X4(4x4 Control Module)																									
Ford	Fusion	3.5L	4V	ABS(Anti-Lock Brake System)																									
Ford	Fusion	3.5L	4V	ACM(Audio Control Module)																									
Ford	Fusion	3.5L	4V	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																									
Ford	Fusion	3.5L	4V	DSP(Digital Signal Processing Module)																									
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																									
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																									
Ford	Fusion	3.5L	4V	FCIM(Front Controls Interface Module)																									
Ford	Fusion	3.5L	4V	FDIM(Front Display Interface Module)																									
Ford	Fusion	3.5L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Fusion	3.5L	4V	GPSM(Global Positioning System Module)																									
Ford	Fusion	3.5L	4V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Fusion	3.5L	4V	IPC(Instrument Panel Control Module)																									
Ford	Fusion	3.5L	4V	OCSM(Occupant Classification System Module)																									
Ford	Fusion	3.5L	4V	PAM(Parking Aid Module)																									
Ford	Fusion	3.5L	4V	PSCM(Power Steering Control Module)																									
Ford	Fusion	3.5L	4V	RCM(Restraint Control Module)																									
Ford	Fusion	3.5L	4V	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Fusion	3.5L	4V	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Fusion	3.5L	4V	TBM(Tracking And Blocking Module)																									
Ford	KA	2000 MY	SYSTEM SEARCH																										
Ford	KA	2000 MY	PCM(PowerTrain Control Module)																										
Ford	KA	2000 MY	ABS(Anti-Lock Brake System)																										
Ford	KA	2000 MY	RCM(Restraint Control Module)																										
Ford	KA	1999 MY	PCM(PowerTrain Control Module)																										
Ford	KA	1999 MY	ABS(Anti-Lock Brake System)																										
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																									
Ford	Kuga	2.0L DIESEL	SYSTEM SEARCH																										
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.0L DIESEL	PCM(PowerTrain Control Module)																										
Ford	Kuga	2.0L DIESEL	TCM(Transmission Control Module)																										
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.0L DIESEL	ABS(Anti-Lock Brake System)																										
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																										
Ford	Kuga	2.0L DIESEL	ACM(Audio Control Module)																										
Ford	Kuga	2.0L DIESEL	AHCM(Auxiliary Heater Control Module)																										
Ford	Kuga	2.0L DIESEL	APIM(Accessory Protocol Interface Module)																										
Ford	Kuga	2.0L DIESEL	AWD(All Wheel Drive Module)																										
Ford	Kuga	2.0L DIESEL	BCMii(Body Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Kuga	2.0L DIESEL	CCMii(Cruise Control Module)																										
Ford	Kuga	2.0L DIESEL	CMR(Camera Module Rear)																										
Ford	Kuga	2.0L DIESEL	D_DCU(Driver Door Control Unit)																										
Ford	Kuga	2.0L DIESEL	DDM(Driver's Door Module)																										
Ford	Kuga	2.0L DIESEL	EATC(Electronic Automatic Temperature Control)																										
Ford	Kuga	2.0L DIESEL	EPS(Electronic Power Steering)																										
Ford	Kuga	2.0L DIESEL	FDSM(Front Distance Sensing Module)																										
Ford	Kuga	2.0L DIESEL	FCDIM(Front Control/Display Interface Module)																										
Ford	Kuga	2.0L DIESEL	FFH(Fuel Fired Coolant Heating Module)																										
Ford	Kuga	2.0L DIESEL	GEM(Generic Electronic Module)																										
Ford	Kuga	2.0L DIESEL	GPSM(Global Positioning System Module)																										
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																										
Ford	Kuga	2.0L DIESEL	HCM(Headlamp Control Module)																										
Ford	Kuga	2.0L DIESEL	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Kuga	2.0L DIESEL	IPM-A(Image Processing Module A)																										
Ford	Kuga	2.0L DIESEL	IPM-B(Image Processing Module B)																										
Ford	Kuga	2.0L DIESEL	IPC(Instrument Panel Control Module)																										
Ford	Kuga	2.0L DIESEL	IC(Instrument Cluster)																										
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																										
Ford	Kuga	2.0L DIESEL	PAM(Parking Aid Module)																										
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																										
Ford	Kuga	2.0L DIESEL	PDM(Passenger's Door Module)																										
Ford	Kuga	2.0L DIESEL	PSCM(Power Steering Control Module)																										
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																										
Ford	Kuga	2.0L DIESEL	RCM(Restraint Control Module)																										
Ford	Kuga	2.0L DIESEL	RFA(Remote Function Actuator)																										
Ford	Kuga	2.0L DIESEL	RGTM(Rear Gate/Trunk Module)																										
Ford	Kuga	2.0L DIESEL	RETM(Rear Entertainment Module)																										
Ford	Kuga	2.0L DIESEL	SASM(Steering Angle Sensor Module)																										
Ford	Kuga	2.0L DIESEL	SOD-L(Side Obstacle Detection Control Module Left)																										
Ford	Kuga	2.0L DIESEL	SOD-R(Side Obstacle Detection Control Module Right)																										
Ford	Kuga	2.0L DIESEL	SRM(Speech Recognition Module)																										
Ford	Kuga	2.0L DIESEL	TRM(Trailer Module)																										
Ford	Kuga	2.5L	I5	SYSTEM SEARCH																									
Ford	Kuga	2.5L	I5	PCM(PowerTrain Control Module)																									
Ford	Kuga	2.5L	I5	ABS(Anti-Lock Brake System)																									
Ford	Kuga	2.5L	I5	ACM(Audio Control Module)																									
Ford	Kuga	2.5L	I5	AWD(All Wheel Drive Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Kuga	2.5L	I5	CMR(Camera Module Rear)																									
Ford	Kuga	2.5L	I5	D_DCU(Driver Door Control Unit)																									
Ford	Kuga	2.5L	I5	EATC(Electronic Automatic Temperature Control)																									
Ford	Kuga	2.5L	I5	EPS(Electronic Power Steering)																									
Ford	Kuga	2.5L	I5	FFH(Fuel Fired Coolant Heating Module)																									
Ford	Kuga	2.5L	I5	GEM(Generic Electronic Module)																									
Ford	Kuga	2.5L	I5	HCM(Headlamp Control Module)																									
Ford	Kuga	2.5L	I5	IC(Instrument Cluster)																									
Ford	Kuga	2.5L	I5	PAM(Parking Aid Module)																									
Ford	Kuga	2.5L	I5	PDM(Passenger's Door Module)																									
Ford	Kuga	2.5L	I5	RCM(Restraint Control Module)																									
Ford	Kuga	2.5L	I5	RETM(Rear Entertainment Module)																									
Ford	Kuga	2.5L	I5	RKE(Remote Keyless Entry)																									
Ford	Kuga	2.5L	I5	SRM(Speech Recognition Module)																									
Ford	Kuga	2.5L	I5	TCM(Transmission Control Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	AHCM(Auxiliary Heater Control Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CCMii(Cruise Control Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	CMR(Camera Module Rear)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	DSM(Driver's Seat Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HCM(Headlamp Control Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PBM(Parking Brake Control Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	PSCM(Power Steering Control Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	RFA(Remote Function Actuator)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SASM(Steering Angle Sensor Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																									
Ford	Mondeo	2010 MY	2.0L Duratorq-Turbo Diesel Common Rail Injection	VDM(Vehicle Dynamic Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Mondeo	2010 MY	2.5L I5	SYSTEM SEARCH																									
Ford	Mondeo	2010 MY	2.5L I5	PCM(PowerTrain Control Module)																									
Ford	Mondeo	2010 MY	2.5L I5	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	2010 MY	2.5L I5	AHCM(Auxiliary Heater Control Module)																									
Ford	Mondeo	2010 MY	2.5L I5	BCMii(Body Control Module)																									
Ford	Mondeo	2010 MY	2.5L I5	CCMii(Cruise Control Module)																									
Ford	Mondeo	2010 MY	2.5L I5	CMR(Camera Module Rear)																									
Ford	Mondeo	2010 MY	2.5L I5	DDM(Driver's Door Module)																									
Ford	Mondeo	2010 MY	2.5L I5	DSM(Driver's Seat Module)																									
Ford	Mondeo	2010 MY	2.5L I5	HCM(Headlamp Control Module)																									
Ford	Mondeo	2010 MY	2.5L I5	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mondeo	2010 MY	2.5L I5	IPC(Instrument Panel Control Module)																									
Ford	Mondeo	2010 MY	2.5L I5	PAM(Parking Aid Module)																									
Ford	Mondeo	2010 MY	2.5L I5	PBM(Parking Brake Control Module)																									
Ford	Mondeo	2010 MY	2.5L I5	PDM(Passenger's Door Module)																									
Ford	Mondeo	2010 MY	2.5L I5	PSCM(Power Steering Control Module)																									
Ford	Mondeo	2010 MY	2.5L I5	RCM(Restraint Control Module)																									
Ford	Mondeo	2010 MY	2.5L I5	RFA(Remote Function Actuator)																									
Ford	Mondeo	2010 MY	2.5L I5	SASM(Steering Angle Sensor Module)																									
Ford	Mondeo	2010 MY	2.5L I5	SRM(Speech Recognition Module)																									
Ford	Mondeo	2010 MY	2.5L I5	TCM(Transmission Control Module)																									
Ford	Mondeo	2010 MY	2.5L I5	TRM(Trailer Module)																									
Ford	Mondeo	2010 MY	2.5L I5	VDM(Vehicle Dynamic Module)																									
Ford	Mondeo	2009 MY	2.0L DIESEL	SYSTEM SEARCH																									
Ford	Mondeo	2009 MY	2.0L DIESEL	PCM(PowerTrain Control Module)																									
Ford	Mondeo	2009 MY	2.0L DIESEL	TCM(Transmission Control Module)																									
Ford	Mondeo	2009 MY	2.0L DIESEL	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	2009 MY	2.0L DIESEL	SASM(Steering Angle Sensor Module)																									
Ford	Mondeo	2009 MY	2.0L DIESEL	RCM(Restraint Control Module)																									
Ford	Mondeo	2009 MY	2.0L DIESEL	IPC(Instrument Panel Control Module)																									
Ford	Mondeo	2009 MY	2.0L DIESEL	BCMii(Body Control Module)																									
Ford	Mondeo	2009 MY	2.0L DIESEL	DDM(Driver's Door Module)																									
Ford	Mondeo	2009 MY	2.0L DIESEL	PDM(Passenger's Door Module)																									
Ford	Mondeo	2009 MY	2.0L DIESEL	SRM(Speech Recognition Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SYSTEM SEARCH																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	AHCM(Auxiliary Heater Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	BCMii(Body Control Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CCMii(Cruise Control Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	CMR(Camera Module Rear)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DDM(Driver's Door Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	DSM(Driver's Seat Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HCM(HeadLamp Control Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	IPC(Instrument Panel Control Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PAM(Parking Aid Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PBM(Parking Brake Control Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PDM(Passenger's Door Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	PSCM(Power Steering Control Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	RFA(Remote Function Actuator)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SASM(Steering Angle Sensor Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	SRM(Speech Recognition Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TCM(Transmission Control Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	TRM(Trailer Module)																									
Ford	Mondeo	2007 MY	2.3L DURATEC-HE/I4	VDM(Vehicle Dynamic Module)																									
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	SYSTEM SEARCH																									
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	PCM(PowerTrain Control Module)																									
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	RCM(Restraint Control Module)																									
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	GEM(Generic Electronic Module)																									
Ford	Mondeo	2003 MY	2.0L Duratorq-Common Diesel	HEC(Hybrid Electrical Cluster)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SYSTEM SEARCH																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	PCM(PowerTrain Control Module)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	ACM(Audio Control Module)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	CDP(Compact Disc Player)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	EATC(Electronic Automatic Temperature Control)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GDM(Generic Display Module)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	GEM(Generic Electronic Module)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	HEC(Hybrid Electrical Cluster)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	LHID(Left High Intensity Discharge Lamp)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	NAV(Navigation System)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RCM(Restraint Control Module)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RETM(Rear Entertainment Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Mondeo	2003 MY	3.0L Duratec-ST	RHID(Right High Intensity Discharge Lamp)																									
Ford	Mondeo	2003 MY	3.0L Duratec-ST	SRM(Speech Recognition Module)																									
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	SYSTEM SEARCH																									
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	PCM(PowerTrain Control Module)																									
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	EATC(Electronic Automatic Temperature Control)																									
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	GEM(Generic Electronic Module)																									
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	HCM(Headlamp Control Module)																									
Ford	Mondeo	2002 MY	2.0L DURATEC HE-I4	RCM(Restraint Control Module)																									
Ford	Mondeo	2000 MY	1.8L	SYSTEM SEARCH																									
Ford	Mondeo	2000 MY	1.8L	PCM(PowerTrain Control Module)																									
Ford	Mondeo	2000 MY	1.8L	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	2000 MY	1.8L	CSM(Central Security Module)																									
Ford	Mondeo	2000 MY	1.8L	PATS(Passive Anti Theft System)																									
Ford	Mondeo	2000 MY	1.8L	RIM(Remote Immobilizer Module)																									
Ford	Mondeo	2000 MY	2.0L	SYSTEM SEARCH																									
Ford	Mondeo	2000 MY	2.0L	PCM(PowerTrain Control Module)																									
Ford	Mondeo	2000 MY	2.0L	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	2000 MY	2.0L	CSM(Central Security Module)																									
Ford	Mondeo	2000 MY	2.5L	SYSTEM SEARCH																									
Ford	Mondeo	2000 MY	2.5L	PCM(PowerTrain Control Module)																									
Ford	Mondeo	2000 MY	2.5L	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	2000 MY	2.5L	CSM(Central Security Module)																									
Ford	Mondeo	1999 MY	1.8L	SYSTEM SEARCH																									
Ford	Mondeo	1999 MY	1.8L	PCM(PowerTrain Control Module)																									
Ford	Mondeo	1999 MY	1.8L	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	1999 MY	1.8L	CSM(Central Security Module)																									
Ford	Mondeo	1999 MY	1.8L	PATS(Passive Anti Theft System)																									
Ford	Mondeo	1999 MY	1.8L	RIM(Remote Immobilizer Module)																									
Ford	Mondeo	1999 MY	2.0L	SYSTEM SEARCH																									
Ford	Mondeo	1999 MY	2.0L	PCM(PowerTrain Control Module)																									
Ford	Mondeo	1999 MY	2.0L	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	1999 MY	2.0L	CSM(Central Security Module)																									
Ford	Mondeo	1999 MY	2.5L	SYSTEM SEARCH																									
Ford	Mondeo	1999 MY	2.5L	PCM(PowerTrain Control Module)																									
Ford	Mondeo	1999 MY	2.5L	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	1999 MY	2.5L	CSM(Central Security Module)																									
Ford	Mondeo	1998 MY	1.8L	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Mondeo	1998 MY	1.8L	PCM(PowerTrain Control Module)																									
Ford	Mondeo	1998 MY	1.8L	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	1998 MY	1.8L	CSM(Central Security Module)																									
Ford	Mondeo	1998 MY	1.8L	PATS(Passive Anti Theft System)																									
Ford	Mondeo	1998 MY	1.8L	RIM(Remote Immobilizer Module)																									
Ford	Mondeo	1998 MY	2.0L	SYSTEM SEARCH																									
Ford	Mondeo	1998 MY	2.0L	PCM(PowerTrain Control Module)																									
Ford	Mondeo	1998 MY	2.0L	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	1998 MY	2.0L	CSM(Central Security Module)																									
Ford	Mondeo	1998 MY	2.5L	SYSTEM SEARCH																									
Ford	Mondeo	1998 MY	2.5L	PCM(PowerTrain Control Module)																									
Ford	Mondeo	1998 MY	2.5L	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	1998 MY	2.5L	CSM(Central Security Module)																									
Ford	Mondeo	1997 MY	1.8L	SYSTEM SEARCH																									
Ford	Mondeo	1997 MY	1.8L	PCM(PowerTrain Control Module)																									
Ford	Mondeo	1997 MY	1.8L	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	1997 MY	1.8L	PATS(Passive Anti Theft System)																									
Ford	Mondeo	1997 MY	1.8L	RIM(Remote Immobilizer Module)																									
Ford	Mondeo	1997 MY	2.0L	PCM(PowerTrain Control Module)																									
Ford	Mondeo	1997 MY	2.0L	ABS(Anti-Lock Brake System)																									
Ford	Mondeo	1997 MY	2.5L	PCM(PowerTrain Control Module)																									
Ford	Mondeo	1997 MY	2.5L	ABS(Anti-Lock Brake System)																									
Ford	Mustang	3.7L	TiVCT	SYSTEM SEARCH																									
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	3.7L	TiVCT	PCM(Powertrain Control Module)																									
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	3.7L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	3.7L	TiVCT	ACM(Audio Control Module)																									
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	3.7L	TiVCT	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	3.7L	TiVCT	BCM-B(Body Control Module B)																									
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	3.7L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Mustang	3.7L	TiVCT	FDIM(Front Display Interface Module)																									
Ford	Mustang	3.7L	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	3.7L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Mustang	3.7L	TiVCT	HVAC(Heating Ventilation Air Conditioning)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Mustang	3.7L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Mustang	3.7L	TiVCT	OCSM(Occupant Classification System Module)																									
Ford	Mustang	3.7L	TiVCT	PAM(Parking Aid Module)																									
Ford	Mustang	3.7L	TiVCT	PSCM(Power Steering Control Module)																									
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	3.7L	TiVCT	RCM(Restraint Control Module)																									
Ford	Mustang	3.8L	SYSTEM SEARCH																										
Ford	Mustang	3.8L	PCM(Powertrain Control Module)																										
Ford	Mustang	3.8L	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.8L	GEM(Generic Electronic Module)																										
Ford	Mustang	3.8L	HEC(Hybrid Electrical Cluster)																										
Ford	Mustang	3.8L	RCM(Restraint Control Module)																										
Ford	Mustang	3.9L	SYSTEM SEARCH																										
Ford	Mustang	3.9L	PCM(Powertrain Control Module)																										
Ford	Mustang	3.9L	ABS(Anti-Lock Brake System)																										
Ford	Mustang	3.9L	GEM(Generic Electronic Module)																										
Ford	Mustang	3.9L	HEC(Hybrid Electrical Cluster)																										
Ford	Mustang	3.9L	RCM(Restraint Control Module)																										
Ford	Mustang	4.0L	V6 (SOHC)	SYSTEM SEARCH																									
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																									
Ford	Mustang	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																									
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	ACM(Audio Control Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	BCM-B(Body Control Module B)																									
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	FCIM(Front Controls Interface Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	FDIM(Front Display Interface Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	4.0L	V6 (SOHC)	GPSM(Global Positioning System Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	4.0L	V6 (SOHC)	IPC(Instrument Panel Control Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	IC(Instrument Cluster)																									
Ford	Mustang	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Mustang	4.0L	V6 (SOHC)	PAM(Parking Aid Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	PSCM(Power Steering Control Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																									
Ford	Mustang	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Mustang	4.0L	V6 (SOHC)	PATS(Passive Anti Theft System)-BETA																									
Ford	Mustang	4.6L	3V	SYSTEM SEARCH																									
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Mustang	4.6L	3V	PCM(Powertrain Control Module)																									
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Mustang	4.6L	3V	ABS(Anti-Lock Brake System)																									
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																									
Ford	Mustang	4.6L	3V	ACM(Audio Control Module)																									
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	4.6L	3V	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	4.6L	3V	BCM-B(Body Control Module B)																									
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																									
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																									
Ford	Mustang	4.6L	3V	FCIM(Front Controls Interface Module)																									
Ford	Mustang	4.6L	3V	FDIM(Front Display Interface Module)																									
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	4.6L	3V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	4.6L	3V	GPSM(Global Positioning System Module)																									
Ford	Mustang	4.6L	3V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																									
Ford	Mustang	4.6L	3V	IPC(Instrument Panel Control Module)																									
Ford	Mustang	4.6L	3V	OCSM(Occupant Classification System Module)																									
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Mustang	4.6L	3V	RCM(Restraint Control Module)																									
Ford	Mustang	4.6L	3V	PATS(Passive Anti Theft System)-BETA																									
Ford	Mustang	5.0L	~ 2014	TiVCT	SYSTEM SEARCH																								
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	PCM(Powertrain Control Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	ABS(Anti-Lock Brake System)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	ACM(Audio Control Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Mustang	5.0L	~ 2014	TiVCT	APIM(Accessory Protocol Interface Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	BCM-B(Body Control Module B)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	FCIM(Front Controls Interface Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	FDIM(Front Display Interface Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	GPSM(Global Positioning System Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	IPC(Instrument Panel Control Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	OCSM(Occupant Classification System Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	PSCM(Power Steering Control Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																								
Ford	Mustang	5.0L	~ 2014	TiVCT	RCM(Restraint Control Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	SYSTEM SEARCH																								
Ford	Mustang	5.0L	2015 ~	TiVCT	PCM(PowerTrain Control Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	ABS(Anti-Lock Brake System)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	ACM(Audio Control Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	APIM(Accessory Protocol Interface Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM(Body Control Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	BCM-B(Body Control Module B)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	C-CM(Cruise Control Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	DACM-C(Digital Audio Control Module C)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	DDM(Driver's Door Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	DSM(Driver's Seat Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	DSP(Digital Signal Processing Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	FCDIM(Front Control/Display Interface Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	FCIM(Front Controls Interface Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	GPSM(Global Positioning System Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	GWM(Gateway Module A)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	HUD(Head Up Display)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	ICM(Information Center Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	IPC(Instrument Panel Control Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-A(Movable Roof Control Module A)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	MRCM-B(Movable Roof Control Module B)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	OCSM(Occupant Classification System Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	PAM(Parking Aid Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	PDM(Passenger's Door Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	PSCM(Power Steering Control Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Mustang	5.0L	2015 ~	TiVCT	RCM(Restraint Control Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	RTM(Radio Transceiver Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	SCCM(Steering Column Control Module)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	SCM-E(Seat Control Module E)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Mustang	5.0L	2015 ~	TiVCT	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Mustang	5.4L	4V	SYSTEM SEARCH																									
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																									
Ford	Mustang	5.4L	4V	PCM(Powertrain Control Module)																									
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.4L	4V	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																									
Ford	Mustang	5.4L	4V	ACM(Audio Control Module)																									
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.4L	4V	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.4L	4V	BCM-B(Body Control Module B)																									
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.4L	4V	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.4L	4V	FDIM(Front Display Interface Module)																									
Ford	Mustang	5.4L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	5.4L	4V	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.4L	4V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	5.4L	4V	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.4L	4V	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.4L	4V	PSCM(Power Steering Control Module)																									
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																									
Ford	Mustang	5.4L	4V	RCM(Restraint Control Module)																									
Ford	Mustang	5.8L	4V	SYSTEM SEARCH																									
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																									
Ford	Mustang	5.8L	4V	PCM(Powertrain Control Module)																									
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.8L	4V	ABS(Anti-Lock Brake System)																									
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																									
Ford	Mustang	5.8L	4V	ACM(Audio Control Module)																									
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.8L	4V	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	5.8L	4V	BCM-B(Body Control Module B)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.8L	4V	FCIM(Front Controls Interface Module)																									
Ford	Mustang	5.8L	4V	FDIM(Front Display Interface Module)																									
Ford	Mustang	5.8L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Mustang	5.8L	4V	GPSM(Global Positioning System Module)																									
Ford	Mustang	5.8L	4V	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Mustang	5.8L	4V	IPC(Instrument Panel Control Module)																									
Ford	Mustang	5.8L	4V	OCSM(Occupant Classification System Module)																									
Ford	Mustang	5.8L	4V	PAM(Parking Aid Module)																									
Ford	Mustang	5.8L	4V	PSCM(Power Steering Control Module)																									
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																									
Ford	Mustang	5.8L	4V	RCM(Restraint Control Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	BCM-B(Body Control Module B)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	ICM(Information Center Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-A(Movable Roof Control Module A)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	MRCM-B(Movable Roof Control Module B)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Mustang	2.3L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																									
Ford	Ranger	2.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																									
Ford	Ranger	2.5 Diesel(WL-CD)	SYSTEM SEARCH																										
Ford	Ranger	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)			V																							
Ford	Ranger	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																										
Ford	Ranger	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																										
Ford	Ranger	2.5 Diesel(WL-CD)	PATS(Passive Anti Theft System)																										
Ford	Ranger	3.0 Diesel(WE-CD)	SYSTEM SEARCH																										
Ford	Ranger	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)			V																							
Ford	Ranger	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																										
Ford	Ranger	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Ranger	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																										
Ford	Ranger	3.0 Diesel(WE-CD)	PATS(Passive Anti Theft System)																										
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)			V																						
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	DDM(Driver's Door Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PDM(Passenger's Door Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TBM(Tracking And Blocking Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TCM(Transmission Control Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	TRM(Trailer Module)																									
Ford	Ranger	3.2 Diesel	Duratorq-Turbo Diesel Common Rail Injection	PATS(Passive Anti Theft System)																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SYSTEM SEARCH																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PCM(Powertrain Control Module)																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	GEM(Generic Electronic Module)																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	IC(Instrument Cluster)																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	4X4(4x4 Control Module)																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Ranger	2.3 Gasoline	DURATEC-HE/I4	PATS(Passive Anti Theft System)																									
Ford	Ranger	2.5 Gasoline	SYSTEM SEARCH																										
Ford	Ranger	2.5 Gasoline	PCM(PowerTrain Control Module)																										
Ford	Ranger	2.5 Gasoline	ABS(Anti-Lock Brake System)																										
Ford	Ranger	2.5 Gasoline	ACM(Audio Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Ranger	2.5 Gasoline	BCMii(Body Control Module)																										
Ford	Ranger	2.5 Gasoline	DDM(Driver's Door Module)																										
Ford	Ranger	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																										
Ford	Ranger	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																										
Ford	Ranger	2.5 Gasoline	IPC(Instrument Panel Control Module)																										
Ford	Ranger	2.5 Gasoline	PAM(Parking Aid Module)																										
Ford	Ranger	2.5 Gasoline	PDM(Passenger's Door Module)																										
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																										
Ford	Ranger	2.5 Gasoline	RCM(Restraint Control Module)																										
Ford	Ranger	2.5 Gasoline	SRM(Speech Recognition Module)																										
Ford	Ranger	2.5 Gasoline	TBM(Tracking And Blocking Module)																										
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																										
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																										
Ford	Ranger	2.5 Gasoline	TCM(Transmission Control Module)																										
Ford	Ranger	2.5 Gasoline	TRM(Trailer Module)																										
Ford	Ranger	2.5 Gasoline	PATS(Passive Anti Theft System)-BETA																										
Ford	Ranger	3.0L	Other	SYSTEM SEARCH																									
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																									
Ford	Ranger	3.0L	Other	PCM(Powertrain Control Module)																									
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																									
Ford	Ranger	3.0L	Other	ABS(Anti-Lock Brake System)																									
Ford	Ranger	3.0L	Other	GEM(Generic Electronic Module)																									
Ford	Ranger	3.0L	Other	IC(Instrument Cluster)																									
Ford	Ranger	3.0L	Other	OCSM(Occupant Classification System Module)																									
Ford	Ranger	3.0L	Other	4X4(4x4 Control Module)																									
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																									
Ford	Ranger	3.0L	Other	RCM(Restraint Control Module)																									
Ford	Ranger	3.0L	Other	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Ranger	3.0L	FFV	SYSTEM SEARCH																									
Ford	Ranger	3.0L	FFV	PCM(Powertrain Control Module)																									
Ford	Ranger	3.0L	FFV	ABS(Anti-Lock Brake System)																									
Ford	Ranger	3.0L	FFV	GEM(Generic Electronic Module)			V																						
Ford	Ranger	3.0L	FFV	PATS(Passive Anti Theft System)																									
Ford	Ranger	3.0L	FFV	RAP(Remote Anti-Theft/Personality Module)																									
Ford	Ranger	3.0L	FFV	RCM(Restraint Control Module)																									
Ford	Ranger	4.0L	V6 (SOHC)	SYSTEM SEARCH																									
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																									
Ford	Ranger	4.0L	V6 (SOHC)	PCM(Powertrain Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Ranger	4.0L	V6 (SOHC)	ABS(Anti-Lock Brake System)																									
Ford	Ranger	4.0L	V6 (SOHC)	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Ford	Ranger	4.0L	V6 (SOHC)	IC(Instrument Cluster)																									
Ford	Ranger	4.0L	V6 (SOHC)	OCSM(Occupant Classification System Module)																									
Ford	Ranger	4.0L	V6 (SOHC)	4X4(4x4 Control Module)																									
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																									
Ford	Ranger	4.0L	V6 (SOHC)	RCM(Restraint Control Module)																									
Ford	Ranger	4.0L	V6 (SOHC)	SDARS(Satellite Digital Audio Receiver System)																									
Ford	Taurus	3.5L	4V	2008 ~ 2009	SYSTEM SEARCH																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	PCM(PowerTrain Control Module)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	4X4(4x4 Control Module)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	ABS(Anti-Lock Brake System)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	ACM(Audio Control Module)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	APIM(Accessory Protocol Interface Module)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	DSM(Driver's Seat Module)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	IC(Instrument Cluster)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	LTM(Liftgate/Trunk Module)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	OCSM(Occupant Classification System Module)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	PAM(Parking Aid Module)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	RCM(Restraint Control Module)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	RETM(Rear Entertainment Module)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	SDARS(Satellite Digital Audio Receiver System)																								
Ford	Taurus	3.5L	4V	2008 ~ 2009	SECM(Steering Effort Control Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	SYSTEM SEARCH																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	PCM(PowerTrain Control Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	4X4(4x4 Control Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	ABS(Anti-Lock Brake System)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	ACM(Audio Control Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	APIM(Accessory Protocol Interface Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	C-CM(Cruise Control Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	DDM(Driver's Door Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSM(Driver's Seat Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Taurus	3.5L	4V	2010 ~ 2012	DSP(Digital Signal Processing Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	FCIM(Front Controls Interface Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	FDIM(Front Display Interface Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	GPSM(Global Positioning System Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM(Headlamp Control Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	HCM-2(Headlamp Control Module2)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	HUD(Head Up Display)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	ILCM(Interior Lighting Control Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	IPC(Instrument Panel Control Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	OCSM(Occupant Classification System Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	PAM(Parking Aid Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	PSCM(Power Steering Control Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	RCM(Restraint Control Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	RETM(Rear Entertainment Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	RFA(Remote Function Actuator)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	SASM(Steering Angle Sensor Module)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Taurus	3.5L	4V	2010 ~ 2012	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	SYSTEM SEARCH																								
Ford	Taurus	3.5L	TiVCT	2013 ~	PCM(PowerTrain Control Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	ABS(Anti-Lock Brake System)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	ACM(Audio Control Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	APIM(Accessory Protocol Interface Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	BCM(Body Control Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	C-CM(Cruise Control Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	DDM(Driver's Door Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	DSM(Driver's Seat Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	DSP(Digital Signal Processing Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	FCIM(Front Controls Interface Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	FCDIM(Front Control/Display Interface Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Taurus	3.5L	TiVCT	2013 ~	GFM(Generic Function Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	GPSM(Global Positioning System Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	HCM(Headlamp Control Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	HSWM(Heated Steering Wheel Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	HUD(Head Up Display)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	IPC(Instrument Panel Control Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	OCSM(Occupant Classification System Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	PAM(Parking Aid Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	PSCM(Power Steering Control Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	RACM(Rear Audio Control Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	RCM(Restraint Control Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	RFA(Remote Function Actuator)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	RTM(Radio Transceiver Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	SCCM(Steering Column Control Module)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Taurus	3.5L	TiVCT	2013 ~	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SYSTEM SEARCH																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PCM(PowerTrain Control Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ABS(Anti-Lock Brake System)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	4X4(4x4 Control Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ACM(Audio Control Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	APIM(Accessory Protocol Interface Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	C-CM(Cruise Control Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DDM(Driver's Door Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSM(Driver's Seat Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	DSP(Digital Signal Processing Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FCIM(Front Controls Interface Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	FDIM(Front Display Interface Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	GPSM(Global Positioning System Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM(Headlamp Control Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HCM-2(Headlamp Control Module2)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HUD(Head Up Display)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	HVAC(Heating Ventilation Air Conditioning)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	ILCM(Interior Lighting Control Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	IPC(Instrument Panel Control Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	OCSM(Occupant Classification System Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PAM(Parking Aid Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	PSCM(Power Steering Control Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RCM(Restraint Control Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RETM(Rear Entertainment Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	RFA(Remote Function Actuator)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SASM(Steering Angle Sensor Module)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																								
Ford	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																								
Ford	Taurus	3.0L	2000 ~	SYSTEM SEARCH																									
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.0L	2000 ~	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.0L	2000 ~	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.0L	2000 ~	EATC(Electronic Automatic Temperature Control)																									
Ford	Taurus	3.0L	2000 ~	GEM(Generic Electronic Module)																									
Ford	Taurus	3.0L	2000 ~	IC(Instrument Cluster)																									
Ford	Taurus	3.0L	2000 ~	RCM(Restraint Control Module)																									
Ford	Taurus	3.0L	~ 1999	SYSTEM SEARCH																									
Ford	Taurus	3.0L	~ 1999	PCM(PowerTrain Control Module)																									
Ford	Taurus	3.0L	~ 1999	ABS(Anti-Lock Brake System)																									
Ford	Taurus	3.0L	~ 1999	RCM(Restraint Control Module)																									
Ford	Taurus	3.0L	~ 1999	RIM(Remote Immobilizer Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM(Driver-Dual Climate Control Seat Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Ford	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SYSTEM SEARCH																									
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PCM(PowerTrain Control Module)																									
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ABS(Anti-Lock Brake System)																									
Ford	Transit	1.8L DIESEL	2007 ~ 2009	ACM(Audio Control Module)																									
Ford	Transit	1.8L DIESEL	2007 ~ 2009	GEM(Generic Electronic Module)																									
Ford	Transit	1.8L DIESEL	2007 ~ 2009	IC(Instrument Cluster)																									
Ford	Transit	1.8L DIESEL	2007 ~ 2009	PAM(Parking Aid Module)																									
Ford	Transit	1.8L DIESEL	2007 ~ 2009	RCM(Restraint Control Module)																									
Ford	Transit	1.8L DIESEL	2007 ~ 2009	SRM(Speech Recognition Module)																									
Ford	Transit	2.0L	2001 ~ 2004	SYSTEM SEARCH																									
Ford	Transit	2.0L	2001 ~ 2004	PCM(PowerTrain Control Module)																									
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)				V	V																				
Ford	Transit	2.0L	2001 ~ 2004	ASM(Auto Shift Manual)						V	V	V	V	V															
Ford	Transit	2.0L	2001 ~ 2004	ABS(Anti-Lock Brake System)																									
Ford	Transit	2.0L	2001 ~ 2004	HEC(Hybrid Electrical Cluster)																									
Ford	Transit	2.0L	2001 ~ 2004	PATS(Passive Anti Theft System)																									
Ford	Transit	2.3L DIESEL	2004 ~ 2006	SYSTEM SEARCH																									
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)											V	V	V	V	V	V									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Transit	2.3L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)					V	V																			
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)							V	V	V	V	V														
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																		V	V						
Ford	Transit	2.3L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																				V					
Ford	Transit	2.3L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																									
Ford	Transit	2.3L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																									
Ford	Transit	2.3L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																					V	V			
Ford	Transit	2.3L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																									
Ford	Transit	2.4L DIESEL	2004 ~ 2006	SYSTEM SEARCH																									
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)																									
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PCM(PowerTrain Control Module)												V	V	V	V	V	V								
Ford	Transit	2.4L DIESEL	2004 ~ 2006	PATS(Passive Anti Theft System)					V	V																			
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ASM(Auto Shift Manual)							V	V	V	V	V														
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																									
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ABS(Anti-Lock Brake System)																		V	V						
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																									
Ford	Transit	2.4L DIESEL	2004 ~ 2006	RCM(Restraint Control Module)																				V					
Ford	Transit	2.4L DIESEL	2004 ~ 2006	HEC(Hybrid Electrical Cluster)																									
Ford	Transit	2.4L DIESEL	2004 ~ 2006	IPC(Instrument Panel Control Module)																									
Ford	Transit	2.4L DIESEL	2004 ~ 2006	BCMii(Body Control Module)																					V	V			
Ford	Transit	2.4L DIESEL	2004 ~ 2006	CSM(Central Security Module)																									
Ford	Transit	2.4L DIESEL	2004 ~ 2006	ACM(Audio Control Module)																									
Ford	Transit	2.4L DIESEL	2006.5	SYSTEM SEARCH																									
Ford	Transit	2.4L DIESEL	2006.5	PCM(PowerTrain Control Module)												V	V	V	V										
Ford	Transit	2.4L DIESEL	2006.5	ABS(Anti-Lock Brake System)																		V	V						
Ford	Transit	2.4L DIESEL	2006.5	ACM(Audio Control Module)																									
Ford	Transit	2.4L DIESEL	2006.5	BCMii(Body Control Module)																									
Ford	Transit	2.4L DIESEL	2006.5	FFH(Fuel Fired Coolant Heating Module)																									
Ford	Transit	2.4L DIESEL	2006.5	IPC(Instrument Panel Control Module)																									
Ford	Transit	2.4L DIESEL	2006.5	PAM(Parking Aid Module)																									
Ford	Transit	2.4L DIESEL	2006.5	RCM(Restraint Control Module)																									
Ford	Transit	2.4L DIESEL	2006.5	TBM(Tracking And Blocking Module)																									
Ford	Transit	2.5L DIESEL	SYSTEM SEARCH																										
Ford	Transit	2.5L DIESEL	PCM(PowerTrain Control Module)																										
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)						V	V																			
Ford	Transit	2.5L DIESEL	ASM(Auto Shift Manual)								V	V	V	V	V														
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(-2000MY)																									
Ford	Transit	2.5L DIESEL	ABS(Anti-Lock Brake System)	ABS(2000MY-)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Transit	2.5L DIESEL	RCM(Restraint Control Module)																										
Ford	Transit	2.5L DIESEL	HEC(Hybrid Electrical Cluster)																										
Ford	Transit	2.5L DIESEL	CSM(Central Security Module)																										
Ford	Transit	2.5L DIESEL	PATS(Passive Anti Theft System)																										
Ford	Transit	2.5L DIESEL	RIM(Remote Immobilizer Module)																										
Ford	Transit	2.5L DIESEL	ACM(Audio Control Module)																										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																									
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)												V	V	V	V										
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																		V	V						
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																									
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	BCMii(Body Control Module)																									
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	FFH(Fuel Fired Coolant Heating Module)																									
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	IPC(Instrument Panel Control Module)																									
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																									
Ford	Transit	3.2L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Control Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B(Image Processing Module B)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Park Aid Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC(Trailer Brake Control Module)																									
Ford	Transit	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																									
Ford	Transit	3.7L	TiVCT	SYSTEM SEARCH																									
Ford	Transit	3.7L	TiVCT	PCM(PowerTrain Control Module)																									
Ford	Transit	3.7L	TiVCT	ABS(Anti-Lock Brake System)																									
Ford	Transit	3.7L	TiVCT	ACM(Audio Control Module)																									
Ford	Transit	3.7L	TiVCT	APIM(Accessory Protocol Control Module)																									
Ford	Transit	3.7L	TiVCT	BCM(Body Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Ford	Transit	3.7L	TiVCT	FCDIM(Front Control/Display Interface Module)																									
Ford	Transit	3.7L	TiVCT	FCIM(Front Controls Interface Module)																									
Ford	Transit	3.7L	TiVCT	GPSM(Global Positioning System Module)																									
Ford	Transit	3.7L	TiVCT	IPC(Instrument Panel Control Module)																									
Ford	Transit	3.7L	TiVCT	IPM-A(Image Processing Module A)																									
Ford	Transit	3.7L	TiVCT	IPM-B(Image Processing Module B)																									
Ford	Transit	3.7L	TiVCT	PAM(Park Aid Module)																									
Ford	Transit	3.7L	TiVCT	RCM(Restraint Control Module)																									
Ford	Transit	3.7L	TiVCT	SASM(Steering Angle Sensor Module)																									
Ford	Transit	3.7L	TiVCT	TBC(Trailer Brake Control Module)																									
Ford	Transit	3.7L	TiVCT	TRM(Trailer Module)																									
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SYSTEM SEARCH																									
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PCM(PowerTrain Control Module)																									
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ABS(Anti-Lock Brake System)																									
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	ACM(Audio Control Module)																									
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	GEM(Generic Electronic Module)																									
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	IC(Instrument Cluster)																									
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	PAM(Parking Aid Module)																									
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	RCM(Restraint Control Module)																									
Ford	Tourneo	1.8L	Duratorq-Turbo Diesel Common Rail Injection	SRM(Speech Recognition Module)																									
Ford	Thunderbird	3.9L	4V	SYSTEM SEARCH																									
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																									
Ford	Thunderbird	3.9L	4V	PCM(PowerTrain Control Module)																									
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																									
Ford	Thunderbird	3.9L	4V	ABS(Anti-Lock Brake System)																									
Ford	Thunderbird	3.9L	4V	ACM(Audio Control Module)																									
Ford	Thunderbird	3.9L	4V	DDM(Driver's Door Module)																									
Ford	Thunderbird	3.9L	4V	EATC(Electronic Automatic Temperature Control)																									
Ford	Thunderbird	3.9L	4V	GEM(Generic Electronic Module)																									
Ford	Thunderbird	3.9L	4V	HEC(Hybrid Electrical Cluster)																									
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																									
Ford	Thunderbird	3.9L	4V	RCM(Restraint Control Module)																									
Ford	Thunderbird	3.9L	4V	REM(Rear Electronic Module)																									
Lincoln	Aviator	4.6L	4V	SYSTEM SEARCH																									
Lincoln	Aviator	4.6L	4V	PCM(Powertrain Control Module)																									
Lincoln	Aviator	4.6L	4V	ABS(Anti-Lock Brake System)																									
Lincoln	Aviator	4.6L	4V	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	Aviator	4.6L	4V	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	Aviator	4.6L	4V	EATC(Electronic Automatic Temperature Control)																									
Lincoln	Aviator	4.6L	4V	IC(Instrument Cluster)																									
Lincoln	Aviator	4.6L	4V	PAM(Parking Aid Module)																									
Lincoln	Aviator	4.6L	4V	RCM(Restraint Control Module)																									
Lincoln	Aviator	4.6L	4V	TPM(Tire Pressure Monitor)																									
Lincoln	Aviator	4.6L	4V	VAPS(Variable Assist Power Steering)																									
Lincoln	Aviator	4.6L	4V	VSM(Vehicle Security Module)																									
Lincoln	Continental	4.6L	4V	SYSTEM SEARCH																									
Lincoln	Continental	4.6L	4V	PCM(PowerTrain Control Module)																									
Lincoln	Continental	4.6L	4V	ABS(Anti-Lock Brake System)																									
Lincoln	Continental	4.6L	4V	ACM(Audio Control Module)																									
Lincoln	Continental	4.6L	4V	CPM(Cellular Phone Module)																									
Lincoln	Continental	4.6L	4V	DDM(Driver's Door Module)																							V		
Lincoln	Continental	4.6L	4V	DSM(Driver's Seat Module)																									
Lincoln	Continental	4.6L	4V	LCM(Lighting Control Module)																									
Lincoln	Continental	4.6L	4V	NGSC(Next Generation Speed Control Module)																									
Lincoln	Continental	4.6L	4V	RCM(Restraint Control Module)																									
Lincoln	Continental	4.6L	4V	VDM(Vehicle Dynamic Module)																									
Lincoln	Continental	4.6L	4V	VIC(Virtual Image Cluster)																									
Lincoln	Continental	4.6L	4V	EATC(Electronic Automatic Temperature Control)																									
Lincoln	Continental	4.6L	4V	PATS(Passive Anti Theft System)																									
Lincoln	LS	ALL	SYSTEM SEARCH																										
Lincoln	LS	ALL	PCM(Powertrain Control Module)																									V	
Lincoln	LS	ALL	PCM(Powertrain Control Module)																										
Lincoln	LS	ALL	ABS(Anti-Lock Brake System)																										
Lincoln	LS	ALL	DCSM(Driver-Dual Climate Control Seat Module)																										
Lincoln	LS	ALL	DDM(Driver's Door Module)																										
Lincoln	LS	ALL	DSM(Driver's Seat Module)																										
Lincoln	LS	ALL	EPB(Electronic Parking Brake)																										
Lincoln	LS	ALL	PAM(Parking Aid Module)																										
Lincoln	LS	ALL	RCM(Restraint Control Module)																										
Lincoln	LS	ALL	REM(Rear Electronic Module)																										
Lincoln	LS	ALL	REM(Rear Electronic Module)																										
Lincoln	LS	ALL	SCLM(Steering Column Locking Module)																										
Lincoln	LS	ALL	EATC(Electronic Automatic Temperature Control)																										
Lincoln	LS	ALL	GEM(Generic Electronic Module)																										
Lincoln	LS	ALL	HEC(Hybrid Electrical Cluster)																										
Lincoln	LS	ALL	PCSM(Passenger Climate Control Seat Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	MKS	3.7L	4V	2009	SYSTEM SEARCH																								
Lincoln	MKS	3.7L	4V	2009	PCM(Powertrain Control Module)																							V	
Lincoln	MKS	3.7L	4V	2009	4X4(4x4 Control Module)																								
Lincoln	MKS	3.7L	4V	2009	ABS(Anti-Lock Brake System)																								
Lincoln	MKS	3.7L	4V	2009	ACM(Audio Control Module)																								
Lincoln	MKS	3.7L	4V	2009	APIM(Accessory Protocol Interface Module)																								
Lincoln	MKS	3.7L	4V	2009	C-CM(Cruise Control Module)																								
Lincoln	MKS	3.7L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																								
Lincoln	MKS	3.7L	4V	2009	DDM(Driver's Door Module)																								
Lincoln	MKS	3.7L	4V	2009	DSM(Driver's Seat Module)																								
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																								
Lincoln	MKS	3.7L	4V	2009	DSP(Digital Signal Processing Module)																								
Lincoln	MKS	3.7L	4V	2009	FCIM(Front Controls Interface Module)																								
Lincoln	MKS	3.7L	4V	2009	FDIM(Front Display Interface Module)																								
Lincoln	MKS	3.7L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Lincoln	MKS	3.7L	4V	2009	HCM(Headlamp Control Module)																								
Lincoln	MKS	3.7L	4V	2009	HCM-2(Headlamp Control Module2)																								
Lincoln	MKS	3.7L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																								
Lincoln	MKS	3.7L	4V	2009	IPC(Instrument Panel Control Module)																								
Lincoln	MKS	3.7L	4V	2009	OCSM(Occupant Classification System Module)																								
Lincoln	MKS	3.7L	4V	2009	PAM(Parking Aid Module)																								
Lincoln	MKS	3.7L	4V	2009	RCM(Restraint Control Module)																								
Lincoln	MKS	3.7L	4V	2009	RFA(Remote Function Actuator)																								
Lincoln	MKS	3.7L	4V	2010 ~	SYSTEM SEARCH																								
Lincoln	MKS	3.7L	4V	2010 ~	PCM(PowerTrain Control Module)																							V	
Lincoln	MKS	3.7L	4V	2010 ~	4X4(4x4 Control Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	ABS(Anti-Lock Brake System)																								
Lincoln	MKS	3.7L	4V	2010 ~	ACM(Audio Control Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	APIM(Accessory Protocol Interface Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	C-CM(Cruise Control Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	DCSM(Driver-Dual Climate Control Seat Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	DDM(Driver's Door Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	DSM(Driver's Seat Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	DSP(Digital Signal Processing Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	FCIM(Front Controls Interface Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	FDIM(Front Display Interface Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	MKS	3.7L	4V	2010 ~	GPSM(Global Positioning System Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	HCM(Headlamp Control Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	HCM-2(Headlamp Control Module2)																								
Lincoln	MKS	3.7L	4V	2010 ~	HUD(Head Up Display)																								
Lincoln	MKS	3.7L	4V	2010 ~	HVAC(Heating Ventilation Air Conditioning)																								
Lincoln	MKS	3.7L	4V	2010 ~	ILCM(Interior Lighting Control Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	IPC(Instrument Panel Control Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	OCSM(Occupant Classification System Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	PAM(Parking Aid Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	PSCM(Power Steering Control Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	RCM(Restraint Control Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	RFA(Remote Function Actuator)																								
Lincoln	MKS	3.7L	4V	2010 ~	SASM(Steering Angle Sensor Module)																								
Lincoln	MKS	3.7L	4V	2010 ~	SOD-L(Side Obstacle Detection Control Module Left)																								
Lincoln	MKS	3.7L	4V	2010 ~	SOD-R(Side Obstacle Detection Control Module Right)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SYSTEM SEARCH																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM(PowerTrain Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS(Anti-Lock Brake System)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	4X4(4x4 Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM(Audio Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	APIM(Accessory Protocol Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	C-CM(Cruise Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DCSM(Driver-Dual Climate Control Seat Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM(Driver's Door Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM(Driver's Seat Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSP(Digital Signal Processing Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FCIM(Front Controls Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	FDIM(Front Display Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	GPSM(Global Positioning System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM(Headlamp Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM-2(Headlamp Control Module2)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HUD(Head Up Display)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC(Heating Ventilation Air Conditioning)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	ILCM(Interior Lighting Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC(Instrument Panel Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	OCSM(Occupant Classification System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM(Parking Aid Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM(Power Steering Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM(Restraint Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA(Remote Function Actuator)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM(Rear Entertainment Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM(Steering Angle Sensor Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L(Side Obstacle Detection Control Module Left)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R(Side Obstacle Detection Control Module Right)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SYSTEM SEARCH																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM(PowerTrain Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS(Anti-Lock Brake System)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	4X4(4x4 Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM(Audio Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM(Accessory Protocol Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	C-CM(Cruise Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DCSM(Driver-Dual Climate Control Seat Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM(Driver's Door Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM(Driver's Seat Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP(Digital Signal Processing Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM(Front Controls Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDIM(Front Display Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	GPSM(Global Positioning System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM(Headlamp Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM-2(Headlamp Control Module2)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HUD(Head Up Display)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC(Heating Ventilation Air Conditioning)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	ILCM(Interior Lighting Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC(Instrument Panel Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	OCSM(Occupant Classification System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM(Parking Aid Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM(Power Steering Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM(Restraint Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA(Remote Function Actuator)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	RETM(Rear Entertainment Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM(Steering Angle Sensor Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L(Side Obstacle Detection Control Module Left)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R(Side Obstacle Detection Control Module Right)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SYSTEM SEARCH																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM(PowerTrain Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ABS(Anti-Lock Brake System)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	4X4(4x4 Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ACM(Audio Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	APIM(Accessory Protocol Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	C-CM(Cruise Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DCSM(Driver-Dual Climate Control Seat Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DDM(Driver's Door Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSM(Driver's Seat Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	DSP(Digital Signal Processing Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCIM(Front Controls Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	FDIM(Front Display Interface Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	GPSM(Global Positioning System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM(Headlamp Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HCM-2(Headlamp Control Module2)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HUD(Head Up Display)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	HVAC(Heating Ventilation Air Conditioning)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	ILCM(Interior Lighting Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	IPC(Instrument Panel Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	OCSM(Occupant Classification System Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PAM(Parking Aid Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	PSCM(Power Steering Control Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RCM(Restraint Control Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RFA(Remote Function Actuator)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	RETM(Rear Entertainment Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SASM(Steering Angle Sensor Module)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-L(Side Obstacle Detection Control Module Left)																								
Lincoln	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2012	SOD-R(Side Obstacle Detection Control Module Right)																								
Lincoln	MKX	3.5L	4V	2007	SYSTEM SEARCH																								
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																								
Lincoln	MKX	3.5L	4V	2007	PCM(Powertrain Control Module)																								
Lincoln	MKX	3.5L	4V	2007	4X4(4x4 Control Module)																								
Lincoln	MKX	3.5L	4V	2007	ABS(Anti-Lock Brake System)																								
Lincoln	MKX	3.5L	4V	2007	ACM(Audio Control Module)																								
Lincoln	MKX	3.5L	4V	2007	DCSM(Driver-Dual Climate Control Seat Module)																								
Lincoln	MKX	3.5L	4V	2007	DSM(Driver's Seat Module)																								
Lincoln	MKX	3.5L	4V	2007	DSP(Digital Signal Processing Module)																								
Lincoln	MKX	3.5L	4V	2007	EATC(Electronic Automatic Temperature Control)																								
Lincoln	MKX	3.5L	4V	2007	GEM(Generic Electronic Module)																								
Lincoln	MKX	3.5L	4V	2007	HCM(Headlamp Control Module)																								
Lincoln	MKX	3.5L	4V	2007	IC(Instrument Cluster)																								
Lincoln	MKX	3.5L	4V	2007	LTM(Liftgate/Trunk Module)																								
Lincoln	MKX	3.5L	4V	2007	OCSM(Occupant Classification System Module)																								
Lincoln	MKX	3.5L	4V	2007	PAM(Parking Aid Module)																								
Lincoln	MKX	3.5L	4V	2007	RCM(Restraint Control Module)																								
Lincoln	MKX	3.5L	4V	2007	RETM(Rear Entertainment Module)																								
Lincoln	MKX	3.5L	4V	2007	SASM(Steering Angle Sensor Module)																								
Lincoln	MKX	3.5L	4V	2007	SDARS(Satellite Digital Audio Receiver System)																								
Lincoln	MKX	3.5L	4V	2008	SYSTEM SEARCH																								
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																								
Lincoln	MKX	3.5L	4V	2008	PCM(Powertrain Control Module)																								
Lincoln	MKX	3.5L	4V	2008	4X4(4x4 Control Module)																								
Lincoln	MKX	3.5L	4V	2008	ABS(Anti-Lock Brake System)																								
Lincoln	MKX	3.5L	4V	2008	ACM(Audio Control Module)																								
Lincoln	MKX	3.5L	4V	2008	APIM(Accessory Protocol Interface Module)																								
Lincoln	MKX	3.5L	4V	2008	DCSM(Driver-Dual Climate Control Seat Module)																								
Lincoln	MKX	3.5L	4V	2008	DSM(Driver's Seat Module)																								
Lincoln	MKX	3.5L	4V	2008	DSP(Digital Signal Processing Module)																								
Lincoln	MKX	3.5L	4V	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Lincoln	MKX	3.5L	4V	2008	HCM(Headlamp Control Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	MKX	3.5L	4V	2008	HVAC(Heating Ventilation Air Conditioning)																								
Lincoln	MKX	3.5L	4V	2008	IC(Instrument Cluster)																								
Lincoln	MKX	3.5L	4V	2008	LTM(Liftgate/Trunk Module)																								
Lincoln	MKX	3.5L	4V	2008	OCSM(Occupant Classification System Module)																								
Lincoln	MKX	3.5L	4V	2008	PAM(Parking Aid Module)																								
Lincoln	MKX	3.5L	4V	2008	RCM(Restraint Control Module)																								
Lincoln	MKX	3.5L	4V	2008	RETM(Rear Entertainment Module)																								
Lincoln	MKX	3.5L	4V	2008	SASM(Steering Angle Sensor Module)																								
Lincoln	MKX	3.5L	4V	2008	SDARS(Satellite Digital Audio Receiver System)																								
Lincoln	MKX	3.5L	4V	2009	SYSTEM SEARCH																								
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																								
Lincoln	MKX	3.5L	4V	2009	PCM(Powertrain Control Module)																								
Lincoln	MKX	3.5L	4V	2009	4X4(4x4 Control Module)																								
Lincoln	MKX	3.5L	4V	2009	ABS(Anti-Lock Brake System)																								
Lincoln	MKX	3.5L	4V	2009	ACM(Audio Control Module)																								
Lincoln	MKX	3.5L	4V	2009	APIM(Accessory Protocol Interface Module)																								
Lincoln	MKX	3.5L	4V	2009	DCSM(Driver-Dual Climate Control Seat Module)																								
Lincoln	MKX	3.5L	4V	2009	DSM(Driver's Seat Module)																								
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																								
Lincoln	MKX	3.5L	4V	2009	DSP(Digital Signal Processing Module)																								
Lincoln	MKX	3.5L	4V	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Lincoln	MKX	3.5L	4V	2009	HCM(Headlamp Control Module)																								
Lincoln	MKX	3.5L	4V	2009	HVAC(Heating Ventilation Air Conditioning)																								
Lincoln	MKX	3.5L	4V	2009	IC(Instrument Cluster)																								
Lincoln	MKX	3.5L	4V	2009	LTM(Liftgate/Trunk Module)																								
Lincoln	MKX	3.5L	4V	2009	OCSM(Occupant Classification System Module)																								
Lincoln	MKX	3.5L	4V	2009	PAM(Parking Aid Module)																								
Lincoln	MKX	3.5L	4V	2009	RCM(Restraint Control Module)																								
Lincoln	MKX	3.5L	4V	2009	RETM(Rear Entertainment Module)																								
Lincoln	MKX	3.5L	4V	2009	SASM(Steering Angle Sensor Module)																								
Lincoln	MKX	3.5L	4V	2009	SDARS(Satellite Digital Audio Receiver System)																								
Lincoln	MKX	3.5L	4V	2010	SYSTEM SEARCH																								
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																								
Lincoln	MKX	3.5L	4V	2010	PCM(Powertrain Control Module)																								
Lincoln	MKX	3.5L	4V	2010	4X4(4x4 Control Module)																								
Lincoln	MKX	3.5L	4V	2010	ABS(Anti-Lock Brake System)																								
Lincoln	MKX	3.5L	4V	2010	ACM(Audio Control Module)																								
Lincoln	MKX	3.5L	4V	2010	APIM(Accessory Protocol Interface Module)																								

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	MKX	3.5L	4V	2010	DCSM(Driver-Dual Climate Control Seat Module)																								
Lincoln	MKX	3.5L	4V	2010	DSM(Driver's Seat Module)																								
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																								
Lincoln	MKX	3.5L	4V	2010	DSP(Digital Signal Processing Module)																								
Lincoln	MKX	3.5L	4V	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																								
Lincoln	MKX	3.5L	4V	2010	HCM(Headlamp Control Module)																								
Lincoln	MKX	3.5L	4V	2010	HVAC(Heating Ventilation Air Conditioning)																								
Lincoln	MKX	3.5L	4V	2010	IC(Instrument Cluster)																								
Lincoln	MKX	3.5L	4V	2010	LTM(Liftgate/Trunk Module)																								
Lincoln	MKX	3.5L	4V	2010	OCSM(Occupant Classification System Module)																								
Lincoln	MKX	3.5L	4V	2010	PAM(Parking Aid Module)																								
Lincoln	MKX	3.5L	4V	2010	RCM(Restraint Control Module)																								
Lincoln	MKX	3.5L	4V	2010	RETM(Rear Entertainment Module)																								
Lincoln	MKX	3.5L	4V	2010	SASM(Steering Angle Sensor Module)																								
Lincoln	MKX	3.5L	4V	2010	SDARS(Satellite Digital Audio Receiver System)																								
Lincoln	MKZ	3.0L	2006	SYSTEM SEARCH																									
Lincoln	MKZ	3.0L	2006	PCM(PowerTrain Control Module)																								V	
Lincoln	MKZ	3.0L	2006	ABS(Anti-Lock Brake System)																									
Lincoln	MKZ	3.0L	2006	ACM(Audio Control Module)																									
Lincoln	MKZ	3.0L	2006	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKZ	3.0L	2006	DDM(Driver's Door Module)																									
Lincoln	MKZ	3.0L	2006	DSM(Driver's Seat Module)																									
Lincoln	MKZ	3.0L	2006	DSP(Digital Signal Processing Module)																									
Lincoln	MKZ	3.0L	2006	EATC(Electronic Automatic Temperature Control)																									
Lincoln	MKZ	3.0L	2006	GEM(Generic Electronic Module)																									
Lincoln	MKZ	3.0L	2006	IC(Instrument Cluster)																									
Lincoln	MKZ	3.0L	2006	OCSM(Occupant Classification System Module)																									
Lincoln	MKZ	3.0L	2006	RCM(Restraint Control Module)																									
Lincoln	MKZ	3.0L	2006	TCM(Transmission Control Module)																									
Lincoln	MKZ	3.5L	2007	SYSTEM SEARCH																									
Lincoln	MKZ	3.5L	2007	PCM(PowerTrain Control Module)																								V	
Lincoln	MKZ	3.5L	2007	TCM(Transmission Control Module)																									
Lincoln	MKZ	3.5L	2007	4X4(4x4 Control Module)																									
Lincoln	MKZ	3.5L	2007	ABS(Anti-Lock Brake System)																									
Lincoln	MKZ	3.5L	2007	ACM(Audio Control Module)																									
Lincoln	MKZ	3.5L	2007	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKZ	3.5L	2007	DDM(Driver's Door Module)																									
Lincoln	MKZ	3.5L	2007	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	MKZ	3.5L	2007	DSP(Digital Signal Processing Module)																									
Lincoln	MKZ	3.5L	2007	EATC(Electronic Automatic Temperature Control)																									
Lincoln	MKZ	3.5L	2007	GEM(Generic Electronic Module)																									
Lincoln	MKZ	3.5L	2007	IC(Instrument Cluster)																									
Lincoln	MKZ	3.5L	2007	OCSM(Occupant Classification System Module)																									
Lincoln	MKZ	3.5L	2007	RCM(Restraint Control Module)																									
Lincoln	MKZ	3.5L	2007	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKZ	3.5L	2007	PATS(Passive Anti Theft System)																									
Lincoln	MKZ	3.5L	2008	SYSTEM SEARCH																									
Lincoln	MKZ	3.5L	2008	PCM(PowerTrain Control Module)																								V	
Lincoln	MKZ	3.5L	2008	4X4(4x4 Control Module)																									
Lincoln	MKZ	3.5L	2008	ABS(Anti-Lock Brake System)																									
Lincoln	MKZ	3.5L	2008	ACM(Audio Control Module)																									
Lincoln	MKZ	3.5L	2008	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKZ	3.5L	2008	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKZ	3.5L	2008	DDM(Driver's Door Module)																									
Lincoln	MKZ	3.5L	2008	DSM(Driver's Seat Module)																									
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																									
Lincoln	MKZ	3.5L	2008	DSP(Digital Signal Processing Module)																									
Lincoln	MKZ	3.5L	2008	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKZ	3.5L	2008	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKZ	3.5L	2008	IC(Instrument Cluster)																									
Lincoln	MKZ	3.5L	2008	OCSM(Occupant Classification System Module)																									
Lincoln	MKZ	3.5L	2008	PAM(Parking Aid Module)																									
Lincoln	MKZ	3.5L	2008	RCM(Restraint Control Module)																									
Lincoln	MKZ	3.5L	2008	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKZ	3.5L	2008	TCM(Transmission Control Module)																									
Lincoln	MKZ	3.5L	2009	SYSTEM SEARCH																									
Lincoln	MKZ	3.5L	2009	PCM(PowerTrain Control Module)																								V	
Lincoln	MKZ	3.5L	2009	4X4(4x4 Control Module)																									
Lincoln	MKZ	3.5L	2009	ABS(Anti-Lock Brake System)																									
Lincoln	MKZ	3.5L	2009	ACM(Audio Control Module)																									
Lincoln	MKZ	3.5L	2009	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKZ	3.5L	2009	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKZ	3.5L	2009	DDM(Driver's Door Module)																									
Lincoln	MKZ	3.5L	2009	DSM(Driver's Seat Module)																									
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																									
Lincoln	MKZ	3.5L	2009	DSP(Digital Signal Processing Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	MKZ	3.5L	2009	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKZ	3.5L	2009	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKZ	3.5L	2009	IC(Instrument Cluster)																									
Lincoln	MKZ	3.5L	2009	OCSM(Occupant Classification System Module)																									
Lincoln	MKZ	3.5L	2009	PAM(Parking Aid Module)																									
Lincoln	MKZ	3.5L	2009	RCM(Restraint Control Module)																									
Lincoln	MKZ	3.5L	2009	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	MKZ	3.5L	2009	TCM(Transmission Control Module)																									
Lincoln	MKZ	3.5L	2010	SYSTEM SEARCH																									
Lincoln	MKZ	3.5L	2010	PCM(PowerTrain Control Module)																								V	
Lincoln	MKZ	3.5L	2010	4X4(4x4 Control Module)																									
Lincoln	MKZ	3.5L	2010	ABS(Anti-Lock Brake System)																									
Lincoln	MKZ	3.5L	2010	ACM(Audio Control Module)																									
Lincoln	MKZ	3.5L	2010	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKZ	3.5L	2010	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	MKZ	3.5L	2010	DDM(Driver's Door Module)																									
Lincoln	MKZ	3.5L	2010	DSM(Driver's Seat Module)																									
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKZ	3.5L	2010	DSP(Digital Signal Processing Module)																									
Lincoln	MKZ	3.5L	2010	FCIM(Front Controls Interface Module)																									
Lincoln	MKZ	3.5L	2010	FDIM(Front Display Interface Module)																									
Lincoln	MKZ	3.5L	2010	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	MKZ	3.5L	2010	GPSM(Global Positioning System Module)																									
Lincoln	MKZ	3.5L	2010	HCM(Headlamp Control Module)																									
Lincoln	MKZ	3.5L	2010	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	MKZ	3.5L	2010	ILCM(Interior Lighting Control Module)																									
Lincoln	MKZ	3.5L	2010	IPC(Instrument Panel Control Module)																									
Lincoln	MKZ	3.5L	2010	OCSM(Occupant Classification System Module)																									
Lincoln	MKZ	3.5L	2010	PAM(Parking Aid Module)																									
Lincoln	MKZ	3.5L	2010	RCM(Restraint Control Module)																									
Lincoln	MKZ	3.5L	2010	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKZ	3.5L	2010	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKZ	3.5L	2010	TCM(Transmission Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACCM(Air Conditioning Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BECM(Battery Energy Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM(Cruise Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C(Digital Audio Control Module C)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCDC(DC to DC Converter Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM(Gateway Module A)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GSM(Gear Shift Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM(Heated Steering Wheel Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD(Head Up Display)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A(Image Processing Module A)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM(Rear Audio Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM(Radio Transceiver Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM(Steering Column Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E(Seat Control Module E)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G(Seat Control Module G)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-H(Seat Control Module H)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRCM(Transmission Range Control Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM(Vehicle Dynamic Module)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOBDM-C(Secondary OBD Control Module C)																									
Lincoln	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM(Generic Function Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SYSTEM SEARCH																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM(PowerTrain Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS(Anti-Lock Brake System)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM(Air Conditioning Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM(Audio Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM(Accessory Protocol Interface Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM(Body Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM(Battery Energy Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM(Cruise Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C(Digital Audio Control Module C)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC(DC to DC Converter Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM(Driver's Door Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM(Driver's Seat Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP(Digital Signal Processing Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM(Front Control/Display Interface Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM(Front Controls Interface Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM(Global Positioning System Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM(Gateway Module A)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM(Gear Shift Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM(Headlamp Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM(Heated Steering Wheel Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD(Head Up Display)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC(Instrument Panel Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A(Image Processing Module A)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM(Occupant Classification System Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM(Parking Aid Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM(Passenger's Door Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM(Power Steering Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM(Rear Audio Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM(Restraint Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM(Rear Gate/Trunk Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM(Radio Transceiver Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM(Steering Column Control Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E(Seat Control Module E)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G(Seat Control Module G)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H(Seat Control Module H)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L(Side Obstacle Detection Control Module Left)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R(Side Obstacle Detection Control Module Right)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM(Transmission Range Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM(Vehicle Dynamic Module)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C(Secondary OBD Control Module C)																									
Lincoln	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM(Generic Function Module)																									
Lincoln	Navigator	2007 ~	5.4L	SYSTEM SEARCH																									
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																									
Lincoln	Navigator	2007 ~	5.4L	PCM(Powertrain Control Module)																									
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																									
Lincoln	Navigator	2007 ~	5.4L	ABS(Anti-Lock Brake System)																									
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																									
Lincoln	Navigator	2007 ~	5.4L	ACM(Audio Control Module)																									
Lincoln	Navigator	2007 ~	5.4L	APIM(Accessory Protocol Interface Module)																									
Lincoln	Navigator	2007 ~	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	Navigator	2007 ~	5.4L	DSM(Driver's Seat Module)																									
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																									
Lincoln	Navigator	2007 ~	5.4L	DSP(Digital Signal Processing Module)																									
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	Navigator	2007 ~	5.4L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Lincoln	Navigator	2007 ~	5.4L	GPSM(Global Positioning System Module)																									
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	Navigator	2007 ~	5.4L	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	Navigator	2007 ~	5.4L	IC(Instrument Cluster)																									
Lincoln	Navigator	2007 ~	5.4L	LTM(Liftgate/Trunk Module)																									
Lincoln	Navigator	2007 ~	5.4L	PAM(Parking Aid Module)																									
Lincoln	Navigator	2007 ~	5.4L	PRB(Power Running Board)																									
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																									
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																									
Lincoln	Navigator	2007 ~	5.4L	RCM(Restraint Control Module)																									
Lincoln	Navigator	2007 ~	5.4L	RCU(Audio Rear Control Unit)																									
Lincoln	Navigator	2007 ~	5.4L	RETM(Rear Entertainment Module)																									
Lincoln	Navigator	2007 ~	5.4L	SDARS(Satellite Digital Audio Receiver System)																									
Lincoln	Navigator	2007 ~	5.4L	TCCM(Transfer Case Control Module)																									
Lincoln	Navigator	2007 ~	5.4L	TCM(Transmission Control Module)																									
Lincoln	Navigator	2007 ~	5.4L	VDM(Vehicle Dynamic Module)																									
Lincoln	Navigator	2007 ~	5.4L	4X4(4x4 Control Module)																									
Lincoln	Navigator	2007 ~	5.4L	PATS(Passive Anti Theft System)																									V
Lincoln	Navigator	~ 2007	5.4L	SYSTEM SEARCH																									
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																									
Lincoln	Navigator	~ 2007	5.4L	PCM(Powertrain Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																									
Lincoln	Navigator	~ 2007	5.4L	ABS(Anti-Lock Brake System)																									
Lincoln	Navigator	~ 2007	5.4L	DCSM(Driver-Dual Climate Control Seat Module)																									
Lincoln	Navigator	~ 2007	5.4L	DSM(Driver's Seat Module)																									
Lincoln	Navigator	~ 2007	5.4L	GEM(Generic Electronic Module)																									
Lincoln	Navigator	~ 2007	5.4L	EATC(Electronic Automatic Temperature Control)																									
Lincoln	Navigator	~ 2007	5.4L	IC(Instrument Cluster)																									
Lincoln	Navigator	~ 2007	5.4L	LTM(Liftgate/Trunk Module)																									
Lincoln	Navigator	~ 2007	5.4L	PAM(Parking Aid Module)																									
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																									
Lincoln	Navigator	~ 2007	5.4L	RCM(Restraint Control Module)																									
Lincoln	Navigator	~ 2007	5.4L	VDM(Vehicle Dynamic Module)																									
Lincoln	Navigator	~ 2007	5.4L	RIM(Remote Immobilizer Module)																									
Lincoln	Navigator	~ 2007	5.4L	VSM(Vehicle Security Module)																									
Lincoln	Town Car	4.6L	2V	SYSTEM SEARCH																									
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																									
Lincoln	Town Car	4.6L	2V	PCM(PowerTrain Control Module)																									
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																									
Lincoln	Town Car	4.6L	2V	ABS(Anti-Lock Brake System)																									
Lincoln	Town Car	4.6L	2V	EATC(Electronic Automatic Temperature Control)																									
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																									
Lincoln	Town Car	4.6L	2V	IC(Instrument Cluster)																									
Lincoln	Town Car	4.6L	2V	LCM(Lighting Control Module)																									
Lincoln	Town Car	4.6L	2V	VDM(Vehicle Dynamic Module)																									
Lincoln	Town Car	4.6L	2V	DDM(Driver's Door Module)																									
Lincoln	Town Car	4.6L	2V	DSM(Driver's Seat Module)																									
Lincoln	Town Car	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Lincoln	Town Car	4.6L	2V	RATC(Rear Air Temperature Control)																									
Lincoln	Town Car	4.6L	2V	LTM(Liftgate/Trunk Module)																									
Lincoln	Town Car	4.6L	2V	PAM(Parking Aid Module)																									
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																									
Lincoln	Town Car	4.6L	2V	RCM(Restraint Control Module)																									
Lincoln	Town Car	4.6L	2V	HEC(Hybrid Electrical Cluster)																									
Lincoln	Town Car	4.6L	2V	NGSC(Next Generation Speed Control Module)																									
Lincoln	Town Car	4.6L	2V	RASM(Rear Air Suspension Module)																									
Mercury	Grand Marquis	4.6L	2V	SYSTEM SEARCH																									
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																									
Mercury	Grand Marquis	4.6L	2V	PCM(Powertrain Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																									
Mercury	Grand Marquis	4.6L	2V	ABS(Anti-Lock Brake System)																									
Mercury	Grand Marquis	4.6L	2V	DDM(Driver's Door Module)																									
Mercury	Grand Marquis	4.6L	2V	IC(Instrument Cluster)																									
Mercury	Grand Marquis	4.6L	2V	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	Grand Marquis	4.6L	2V	LCM(Lighting Control Module)																									
Mercury	Grand Marquis	4.6L	2V	MC(Message Center)																									
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																									
Mercury	Grand Marquis	4.6L	2V	RCM(Restraint Control Module)																									
Mercury	Grand Marquis	4.6L	2V	RIM(Remote Immobilizer Module)																									
Mercury	Grand Marquis	4.6L	2V	GEM(Generic Electronic Module)																									
Mercury	Grand Marquis	4.6L	2V	VDM(Vehicle Dynamic Module)																									
Mercury	Marauder	4.6L	4V	SYSTEM SEARCH																									
Mercury	Marauder	4.6L	4V	PCM(Powertrain Control Module)																									
Mercury	Marauder	4.6L	4V	ABS(Anti-Lock Brake System)																									
Mercury	Marauder	4.6L	4V	EATC(Electronic Automatic Temperature Control)																									
Mercury	Marauder	4.6L	4V	RASM(Rear Air Suspension Module)																									
Mercury	Marauder	4.6L	4V	VAPS(Variable Assist Power Steering)																									
Mercury	Marauder	4.6L	4V	DDM(Driver's Door Module)																									
Mercury	Marauder	4.6L	4V	LCM(Lighting Control Module)																									
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																									
Mercury	Marauder	4.6L	4V	RCM(Restraint Control Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																									
Mercury	Milan	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	DSP(Digital Signal Processing Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	IPC(Instrument Panel Control Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	Milan	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-L(Side Obstacle Detection Control Module Left)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	SOD-R(Side Obstacle Detection Control Module Right)																									
Mercury	Milan	2.5L	DURATEC-HE/I4	TBM(Tracking And Blocking Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SYSTEM SEARCH																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PCM(PowerTrain Control Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TCM(Transmission Control Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	4X4(4x4 Control Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ABS(Anti-Lock Brake System)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACCM(Air Conditioning Control Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	ACM(Audio Control Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	APIM(Accessory Protocol Interface Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	BECM(Battery Energy Control Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DCDC(DC to DC Converter Control Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	DSP(Digital Signal Processing Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FCIM(Front Controls Interface Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	FDIM(Front Display Interface Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	GPSM(Global Positioning System Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	IPC(Instrument Panel Control Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	OCSM(Occupant Classification System Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PAM(Parking Aid Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	PSCM(Power Steering Control Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	RCM(Restraint Control Module)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-L(Side Obstacle Detection Control Module Left)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	SOD-R(Side Obstacle Detection Control Module Right)																									
Mercury	Milan	2.5L	HEV/ATKINSON 4V	TBM(Tracking And Blocking Module)																									
Mercury	Milan	3.0L	4V	SYSTEM SEARCH																									
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																									
Mercury	Milan	3.0L	4V	PCM(PowerTrain Control Module)																									
Mercury	Milan	3.0L	4V	4X4(4x4 Control Module)																									
Mercury	Milan	3.0L	4V	ABS(Anti-Lock Brake System)																									
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																									
Mercury	Milan	3.0L	4V	ACM(Audio Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	Milan	3.0L	4V	APIM(Accessory Protocol Interface Module)																									
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																									
Mercury	Milan	3.0L	4V	DSP(Digital Signal Processing Module)																									
Mercury	Milan	3.0L	4V	FDIM(Front Display Interface Module)																									
Mercury	Milan	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Mercury	Milan	3.0L	4V	GPSM(Global Positioning System Module)																									
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	Milan	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																									
Mercury	Milan	3.0L	4V	IC(Instrument Cluster)																									
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																									
Mercury	Milan	3.0L	4V	OCSM(Occupant Classification System Module)																									
Mercury	Milan	3.0L	4V	PAM(Parking Aid Module)																									
Mercury	Milan	3.0L	4V	PSCM(Power Steering Control Module)																									
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																									
Mercury	Milan	3.0L	4V	RCM(Restraint Control Module)																									
Mercury	Milan	3.0L	4V	SOD-L(Side Obstacle Detection Control Module Left)																									
Mercury	Milan	3.0L	4V	SOD-R(Side Obstacle Detection Control Module Right)																									
Mercury	Milan	3.0L	4V	TCM(Transmission Control Module)																									
Mercury	Milan	3.0L	4V	TBM(Tracking And Blocking Module)																									
Mercury	Milan	3.0L	4V	SDARS(Satellite Digital Audio Receiver System)																									
Mercury	Milan	3.0L	4V	PATS(Passive Anti Theft System)																									
Mercury	Montego	3.0L	4V	SYSTEM SEARCH																									
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																									
Mercury	Montego	3.0L	4V	PCM(PowerTrain Control Module)																									
Mercury	Montego	3.0L	4V	4X4(4x4 Control Module)																									
Mercury	Montego	3.0L	4V	ABS(Anti-Lock Brake System)																									
Mercury	Montego	3.0L	4V	ACM(Audio Control Module)																									
Mercury	Montego	3.0L	4V	DSM(Driver's Seat Module)																									
Mercury	Montego	3.0L	4V	EATC(Electronic Automatic Temperature Control)																									
Mercury	Montego	3.0L	4V	GEM(Generic Electronic Module)																									
Mercury	Montego	3.0L	4V	IC(Instrument Cluster)																									
Mercury	Montego	3.0L	4V	PAM(Parking Aid Module)																									
Mercury	Montego	3.0L	4V	RCM(Restraint Control Module)																									
Mercury	Montego	3.0L	4V	TCM(Transmission Control Module)																									
Mercury	FreestarMonterey	3.9L	SYSTEM SEARCH																										
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																										
Mercury	FreestarMonterey	3.9L	PCM(Powertrain Control Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																										
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																										
Mercury	FreestarMonterey	3.9L	ABS(Anti-Lock Brake System)																										
Mercury	FreestarMonterey	3.9L	DCSM(Driver-Dual Climate Control Seat Module)																										
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																										
Mercury	FreestarMonterey	3.9L	DSM(Driver's Seat Module)																										
Mercury	FreestarMonterey	3.9L	EATC(Electronic Automatic Temperature Control)																										
Mercury	FreestarMonterey	3.9L	GEM(Generic Electronic Module)																										
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																										
Mercury	FreestarMonterey	3.9L	IC(Instrument Cluster)																										
Mercury	FreestarMonterey	3.9L	LTM(Liftgate/Trunk Module)																										
Mercury	FreestarMonterey	3.9L	NGSC(Next Generation Speed Control Module)																										
Mercury	FreestarMonterey	3.9L	PSCM(Power Steering Control Module)																										
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																										
Mercury	FreestarMonterey	3.9L	RCM(Restraint Control Module)																										
Mercury	FreestarMonterey	3.9L	LPSDM(Left Power Sliding Module)																										
Mercury	FreestarMonterey	3.9L	RPSDM(Right Power Sliding Module)																										
Mercury	FreestarMonterey	3.9L	TPM(Tire Pressure Monitor)																										
Mercury	FreestarMonterey	4.2L	SYSTEM SEARCH																										
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																										
Mercury	FreestarMonterey	4.2L	PCM(Powertrain Control Module)																										
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																										
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																										
Mercury	FreestarMonterey	4.2L	ABS(Anti-Lock Brake System)																										
Mercury	FreestarMonterey	4.2L	DCSM(Driver-Dual Climate Control Seat Module)																										
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																										
Mercury	FreestarMonterey	4.2L	DSM(Driver's Seat Module)																										
Mercury	FreestarMonterey	4.2L	EATC(Electronic Automatic Temperature Control)																										
Mercury	FreestarMonterey	4.2L	GEM(Generic Electronic Module)																										
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																										
Mercury	FreestarMonterey	4.2L	IC(Instrument Cluster)																										
Mercury	FreestarMonterey	4.2L	LTM(Liftgate/Trunk Module)																										
Mercury	FreestarMonterey	4.2L	NGSC(Next Generation Speed Control Module)																										
Mercury	FreestarMonterey	4.2L	PSCM(Power Steering Control Module)																										
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																										
Mercury	FreestarMonterey	4.2L	RCM(Restraint Control Module)																										
Mercury	FreestarMonterey	4.2L	LPSDM(Left Power Sliding Module)																										
Mercury	FreestarMonterey	4.2L	RPSDM(Right Power Sliding Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	FreestarMonterey	4.2L	TPM(Tire Pressure Monitor)																										
Mercury	Mountaineer	2010 MY	4.6L	SYSTEM SEARCH																									
Mercury	Mountaineer	2010 MY	4.6L	PCM(Powertrain Control Module)																									
Mercury	Mountaineer	2010 MY	4.6L	TCM(Transmission Control Module)																									
Mercury	Mountaineer	2010 MY	4.6L	4X4(4x4 Control Module)																									
Mercury	Mountaineer	2010 MY	4.6L	ABS(Anti-Lock Brake System)																									
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2010 MY	4.6L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2010 MY	4.6L	APIM(Accessory Protocol Interface Module)																									
Mercury	Mountaineer	2010 MY	4.6L	GPSM(Global Positioning System Module)																									
Mercury	Mountaineer	2010 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	Mountaineer	2010 MY	4.6L	DSM(Driver's Seat Module)																									
Mercury	Mountaineer	2010 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Mercury	Mountaineer	2010 MY	4.6L	IC(Instrument Cluster)																									
Mercury	Mountaineer	2010 MY	4.6L	OCSM(Occupant Classification System Module)																									
Mercury	Mountaineer	2010 MY	4.6L	PAM(Parking Aid Module)																									
Mercury	Mountaineer	2010 MY	4.6L	PRB(Power Running Board)																									
Mercury	Mountaineer	2010 MY	4.6L	RCM(Restraint Control Module)																									
Mercury	Mountaineer	2010 MY	4.6L	RETM(Rear Entertainment Module)																									
Mercury	Mountaineer	2010 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																									
Mercury	Mountaineer	2010 MY	4.0L	SYSTEM SEARCH																									
Mercury	Mountaineer	2010 MY	4.0L	PCM(Powertrain Control Module)																									
Mercury	Mountaineer	2010 MY	4.0L	4X4(4x4 Control Module)																									
Mercury	Mountaineer	2010 MY	4.0L	ABS(Anti-Lock Brake System)																									
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2010 MY	4.0L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2010 MY	4.0L	DSM(Driver's Seat Module)																									
Mercury	Mountaineer	2010 MY	4.0L	EATC(Electronic Automatic Temperature Control)																									
Mercury	Mountaineer	2010 MY	4.0L	GEM(Generic Electronic Module)																									
Mercury	Mountaineer	2010 MY	4.0L	IC(Instrument Cluster)																									
Mercury	Mountaineer	2010 MY	4.0L	OCSM(Occupant Classification System Module)																									
Mercury	Mountaineer	2010 MY	4.0L	PAM(Parking Aid Module)																									
Mercury	Mountaineer	2010 MY	4.0L	PRB(Power Running Board)																									
Mercury	Mountaineer	2010 MY	4.0L	RCM(Restraint Control Module)																									
Mercury	Mountaineer	2010 MY	4.0L	RETM(Rear Entertainment Module)																									
Mercury	Mountaineer	2010 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																									
Mercury	Mountaineer	2009 MY	4.6L	SYSTEM SEARCH																									
Mercury	Mountaineer	2009 MY	4.6L	PCM(Powertrain Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	Mountaineer	2009 MY	4.6L	TCM(Transmission Control Module)																									
Mercury	Mountaineer	2009 MY	4.6L	4X4(4x4 Control Module)																									
Mercury	Mountaineer	2009 MY	4.6L	ABS(Anti-Lock Brake System)																									
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2009 MY	4.6L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2009 MY	4.6L	APIM(Accessory Protocol Interface Module)																									
Mercury	Mountaineer	2009 MY	4.6L	GPSM(Global Positioning System Module)																									
Mercury	Mountaineer	2009 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	Mountaineer	2009 MY	4.6L	DSM(Driver's Seat Module)																									
Mercury	Mountaineer	2009 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Mercury	Mountaineer	2009 MY	4.6L	IC(Instrument Cluster)																									
Mercury	Mountaineer	2009 MY	4.6L	OCSM(Occupant Classification System Module)																									
Mercury	Mountaineer	2009 MY	4.6L	PAM(Parking Aid Module)																									
Mercury	Mountaineer	2009 MY	4.6L	PRB(Power Running Board)																									
Mercury	Mountaineer	2009 MY	4.6L	RCM(Restraint Control Module)																									
Mercury	Mountaineer	2009 MY	4.6L	RETM(Rear Entertainment Module)																									
Mercury	Mountaineer	2009 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																									
Mercury	Mountaineer	2009 MY	4.0L	SYSTEM SEARCH																									
Mercury	Mountaineer	2009 MY	4.0L	PCM(Powertrain Control Module)																									
Mercury	Mountaineer	2009 MY	4.0L	4X4(4x4 Control Module)																									
Mercury	Mountaineer	2009 MY	4.0L	ABS(Anti-Lock Brake System)																									
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2009 MY	4.0L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2009 MY	4.0L	DSM(Driver's Seat Module)																									
Mercury	Mountaineer	2009 MY	4.0L	EATC(Electronic Automatic Temperature Control)																									
Mercury	Mountaineer	2009 MY	4.0L	GEM(Generic Electronic Module)																									
Mercury	Mountaineer	2009 MY	4.0L	IC(Instrument Cluster)																									
Mercury	Mountaineer	2009 MY	4.0L	OCSM(Occupant Classification System Module)																									
Mercury	Mountaineer	2009 MY	4.0L	PAM(Parking Aid Module)																									
Mercury	Mountaineer	2009 MY	4.0L	PRB(Power Running Board)																									
Mercury	Mountaineer	2009 MY	4.0L	RCM(Restraint Control Module)																									
Mercury	Mountaineer	2009 MY	4.0L	RETM(Rear Entertainment Module)																									
Mercury	Mountaineer	2009 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																									
Mercury	Mountaineer	2008 MY	4.6L	SYSTEM SEARCH																									
Mercury	Mountaineer	2008 MY	4.6L	PCM(Powertrain Control Module)																									
Mercury	Mountaineer	2008 MY	4.6L	TCM(Transmission Control Module)																									
Mercury	Mountaineer	2008 MY	4.6L	4X4(4x4 Control Module)																									
Mercury	Mountaineer	2008 MY	4.6L	ABS(Anti-Lock Brake System)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2008 MY	4.6L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2008 MY	4.6L	APIM(Accessory Protocol Interface Module)																									
Mercury	Mountaineer	2008 MY	4.6L	GPSM(Global Positioning System Module)																									
Mercury	Mountaineer	2008 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	Mountaineer	2008 MY	4.6L	DSM(Driver's Seat Module)																									
Mercury	Mountaineer	2008 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Mercury	Mountaineer	2008 MY	4.6L	IC(Instrument Cluster)																									
Mercury	Mountaineer	2008 MY	4.6L	OCSM(Occupant Classification System Module)																									
Mercury	Mountaineer	2008 MY	4.6L	PAM(Parking Aid Module)																									
Mercury	Mountaineer	2008 MY	4.6L	PRB(Power Running Board)																									
Mercury	Mountaineer	2008 MY	4.6L	RCM(Restraint Control Module)																									
Mercury	Mountaineer	2008 MY	4.6L	RETM(Rear Entertainment Module)																									
Mercury	Mountaineer	2008 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																									
Mercury	Mountaineer	2008 MY	4.0L	SYSTEM SEARCH																									
Mercury	Mountaineer	2008 MY	4.0L	PCM(Powertrain Control Module)																									
Mercury	Mountaineer	2008 MY	4.0L	4X4(4x4 Control Module)																									
Mercury	Mountaineer	2008 MY	4.0L	ABS(Anti-Lock Brake System)																									
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2008 MY	4.0L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2008 MY	4.0L	DSM(Driver's Seat Module)																									
Mercury	Mountaineer	2008 MY	4.0L	EATC(Electronic Automatic Temperature Control)																									
Mercury	Mountaineer	2008 MY	4.0L	GEM(Generic Electronic Module)																									
Mercury	Mountaineer	2008 MY	4.0L	IC(Instrument Cluster)																									
Mercury	Mountaineer	2008 MY	4.0L	OCSM(Occupant Classification System Module)																									
Mercury	Mountaineer	2008 MY	4.0L	PAM(Parking Aid Module)																									
Mercury	Mountaineer	2008 MY	4.0L	PRB(Power Running Board)																									
Mercury	Mountaineer	2008 MY	4.0L	RCM(Restraint Control Module)																									
Mercury	Mountaineer	2008 MY	4.0L	RETM(Rear Entertainment Module)																									
Mercury	Mountaineer	2008 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																									
Mercury	Mountaineer	2007 MY	4.6L	SYSTEM SEARCH																									
Mercury	Mountaineer	2007 MY	4.6L	PCM(Powertrain Control Module)																									
Mercury	Mountaineer	2007 MY	4.6L	TCM(Transmission Control Module)																									
Mercury	Mountaineer	2007 MY	4.6L	4X4(4x4 Control Module)																									
Mercury	Mountaineer	2007 MY	4.6L	ABS(Anti-Lock Brake System)																									
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2007 MY	4.6L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2007 MY	4.6L	APIM(Accessory Protocol Interface Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Igniton key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	Mountaineer	2007 MY	4.6L	GPSM(Global Positioning System Module)																									
Mercury	Mountaineer	2007 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	Mountaineer	2007 MY	4.6L	DSM(Driver's Seat Module)																									
Mercury	Mountaineer	2007 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Mercury	Mountaineer	2007 MY	4.6L	IC(Instrument Cluster)																									
Mercury	Mountaineer	2007 MY	4.6L	OCSM(Occupant Classification System Module)																									
Mercury	Mountaineer	2007 MY	4.6L	PAM(Parking Aid Module)																									
Mercury	Mountaineer	2007 MY	4.6L	PRB(Power Running Board)																									
Mercury	Mountaineer	2007 MY	4.6L	RCM(Restraint Control Module)																									
Mercury	Mountaineer	2007 MY	4.6L	RETM(Rear Entertainment Module)																									
Mercury	Mountaineer	2007 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																									
Mercury	Mountaineer	2007 MY	4.0L	SYSTEM SEARCH																									
Mercury	Mountaineer	2007 MY	4.0L	PCM(Powertrain Control Module)																									
Mercury	Mountaineer	2007 MY	4.0L	4X4(4x4 Control Module)																									
Mercury	Mountaineer	2007 MY	4.0L	ABS(Anti-Lock Brake System)																									
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2007 MY	4.0L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2007 MY	4.0L	DSM(Driver's Seat Module)																									
Mercury	Mountaineer	2007 MY	4.0L	EATC(Electronic Automatic Temperature Control)																									
Mercury	Mountaineer	2007 MY	4.0L	GEM(Generic Electronic Module)																									
Mercury	Mountaineer	2007 MY	4.0L	IC(Instrument Cluster)																									
Mercury	Mountaineer	2007 MY	4.0L	OCSM(Occupant Classification System Module)																									
Mercury	Mountaineer	2007 MY	4.0L	PAM(Parking Aid Module)																									
Mercury	Mountaineer	2007 MY	4.0L	PRB(Power Running Board)																									
Mercury	Mountaineer	2007 MY	4.0L	RCM(Restraint Control Module)																									
Mercury	Mountaineer	2007 MY	4.0L	RETM(Rear Entertainment Module)																									
Mercury	Mountaineer	2007 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																									
Mercury	Mountaineer	2006 MY	4.6L	SYSTEM SEARCH																									
Mercury	Mountaineer	2006 MY	4.6L	PCM(Powertrain Control Module)																									
Mercury	Mountaineer	2006 MY	4.6L	TCM(Transmission Control Module)																									
Mercury	Mountaineer	2006 MY	4.6L	4X4(4x4 Control Module)																									
Mercury	Mountaineer	2006 MY	4.6L	ABS(Anti-Lock Brake System)																									
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2006 MY	4.6L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2006 MY	4.6L	APIM(Accessory Protocol Interface Module)																									
Mercury	Mountaineer	2006 MY	4.6L	GPSM(Global Positioning System Module)																									
Mercury	Mountaineer	2006 MY	4.6L	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	Mountaineer	2006 MY	4.6L	DSM(Driver's Seat Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	Mountaineer	2006 MY	4.6L	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Mercury	Mountaineer	2006 MY	4.6L	IC(Instrument Cluster)																									
Mercury	Mountaineer	2006 MY	4.6L	OCSM(Occupant Classification System Module)																									
Mercury	Mountaineer	2006 MY	4.6L	PAM(Parking Aid Module)																									
Mercury	Mountaineer	2006 MY	4.6L	PRB(Power Running Board)																									
Mercury	Mountaineer	2006 MY	4.6L	RCM(Restraint Control Module)																									
Mercury	Mountaineer	2006 MY	4.6L	RETM(Rear Entertainment Module)																									
Mercury	Mountaineer	2006 MY	4.6L	SDARS(Satellite Digital Audio Receiver System)																									
Mercury	Mountaineer	2006 MY	4.0L	SYSTEM SEARCH																									
Mercury	Mountaineer	2006 MY	4.0L	PCM(Powertrain Control Module)																									
Mercury	Mountaineer	2006 MY	4.0L	4X4(4x4 Control Module)																									
Mercury	Mountaineer	2006 MY	4.0L	ABS(Anti-Lock Brake System)																									
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2006 MY	4.0L	ACM(Audio Control Module)																									
Mercury	Mountaineer	2006 MY	4.0L	DSM(Driver's Seat Module)																									
Mercury	Mountaineer	2006 MY	4.0L	EATC(Electronic Automatic Temperature Control)																									
Mercury	Mountaineer	2006 MY	4.0L	GEM(Generic Electronic Module)																									
Mercury	Mountaineer	2006 MY	4.0L	IC(Instrument Cluster)																									
Mercury	Mountaineer	2006 MY	4.0L	OCSM(Occupant Classification System Module)																									
Mercury	Mountaineer	2006 MY	4.0L	PAM(Parking Aid Module)																									
Mercury	Mountaineer	2006 MY	4.0L	PRB(Power Running Board)																									
Mercury	Mountaineer	2006 MY	4.0L	RCM(Restraint Control Module)																									
Mercury	Mountaineer	2006 MY	4.0L	RETM(Rear Entertainment Module)																									
Mercury	Mountaineer	2006 MY	4.0L	SDARS(Satellite Digital Audio Receiver System)																									
Mercury	Mountaineer	2003 MY	SYSTEM SEARCH																										
Mercury	Mountaineer	2003 MY	PCM(PowerTrain Control Module)																										
Mercury	Mountaineer	2003 MY	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2003 MY	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2003 MY	RIM(Remote Immobilizer Module)																										
Mercury	Mountaineer	2003 MY	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2003 MY	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																										
Mercury	Mountaineer	2003 MY	PATS(Passive Anti Theft System)																										
Mercury	Mountaineer	2002 MY	SYSTEM SEARCH																										
Mercury	Mountaineer	2002 MY	PCM(PowerTrain Control Module)																										
Mercury	Mountaineer	2002 MY	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2002 MY	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2002 MY	RIM(Remote Immobilizer Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	Mountaineer	2002 MY	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2002 MY	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																										
Mercury	Mountaineer	2002 MY	PATS(Passive Anti Theft System)																										
Mercury	Mountaineer	2001 MY	SYSTEM SEARCH																										
Mercury	Mountaineer	2001 MY	PCM(PowerTrain Control Module)																										
Mercury	Mountaineer	2001 MY	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2001 MY	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2001 MY	RIM(Remote Immobilizer Module)																										
Mercury	Mountaineer	2001 MY	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2001 MY	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																										
Mercury	Mountaineer	2001 MY	PATS(Passive Anti Theft System)																										
Mercury	Mountaineer	2000 MY	SYSTEM SEARCH																										
Mercury	Mountaineer	2000 MY	PCM(PowerTrain Control Module)																										
Mercury	Mountaineer	2000 MY	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	2000 MY	RCM(Restraint Control Module)																										
Mercury	Mountaineer	2000 MY	RIM(Remote Immobilizer Module)																										
Mercury	Mountaineer	2000 MY	GEM(Generic Electronic Module)																										
Mercury	Mountaineer	2000 MY	PAM(Parking Aid Module)																										
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																										
Mercury	Mountaineer	2000 MY	PATS(Passive Anti Theft System)																										
Mercury	Mountaineer	1999 MY	SYSTEM SEARCH																										
Mercury	Mountaineer	1999 MY	PCM(PowerTrain Control Module)																										
Mercury	Mountaineer	1999 MY	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	1999 MY	RCM(Restraint Control Module)																										
Mercury	Mountaineer	1999 MY	RIM(Remote Immobilizer Module)																										
Mercury	Mountaineer	1999 MY	PAM(Parking Aid Module)																										
Mercury	Mountaineer	1998 MY	SYSTEM SEARCH																										
Mercury	Mountaineer	1998 MY	PCM(PowerTrain Control Module)																										
Mercury	Mountaineer	1998 MY	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	1998 MY	RCM(Restraint Control Module)																										
Mercury	Mountaineer	1998 MY	RIM(Remote Immobilizer Module)																										
Mercury	Mountaineer	1997 MY	SYSTEM SEARCH																										
Mercury	Mountaineer	1997 MY	PCM(PowerTrain Control Module)																										
Mercury	Mountaineer	1997 MY	ABS(Anti-Lock Brake System)																										
Mercury	Mountaineer	1997 MY	RCM(Restraint Control Module)																										
Mercury	Mountaineer	1997 MY	RIM(Remote Immobilizer Module)																										

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									
Mercury	EscapeTributeMarinerMarverick	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SYSTEM SEARCH																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM(PowerTrain Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS(Anti-Lock Brake System)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM(Audio Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM(Accessory Protocol Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM(Body Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM(Driver's Door Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM(Driver's Seat Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP(Digital Signal Processing Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM(Front Controls Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM(Front Control/Display Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM(Global Positioning System Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM(Headlamp Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC(Instrument Panel Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM(Occupant Classification System Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM(Parking Aid Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM(Passenger's Door Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM(Power Steering Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM(Restraint Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA(Remote Function Actuator)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM(Rear Gate/Trunk Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM(Steering Angle Sensor Module)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L(Side Obstacle Detection Control Module Left)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R(Side Obstacle Detection Control Module Right)																									
Mercury	EscapeTributeMarinerMarverick	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM(Trailer Module)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SYSTEM SEARCH																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	TCM(Transmission Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	4X4(4x4 Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	IC(Instrument Cluster)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	RCM(Restraint Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	SDARS(Satellite Digital Audio Receiver System)																									
Mercury	EscapeTributeMarinerMarverick	2.3L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	SYSTEM SEARCH																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PCM(PowerTrain Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	4X4(4x4 Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ABS(Anti-Lock Brake System)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	ACM(Audio Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	APIM(Accessory Protocol Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FCIM(Front Controls Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	FDIM(Front Display Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	GPSM(Global Positioning System Module)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	IC(Instrument Cluster)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	OCSM(Occupant Classification System Module)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PAM(Parking Aid Module)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PSCM(Power Steering Control Module)																									
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	RCM(Restraint Control Module)																									

Maker	Vehicle	Capacity	Systam 1	Systam 2	Systam 3	MAF sensor reset	Ambient Air Temp Sensor Configuration	Windshield Wiper Test	Ignition keys erase	Ignition keys program	Depressurize ASM system	Shift actuator bleed	Learn transmission	Learn Clutch Parameter	Learn clutch touch point	Fuel injector pilot correction learn	Fuel injection pump learn	DPF regeneration	Reset the exhaust gas temperature value	Reset the fuel pressure relief valve open count learned value	Reset the fuel pressure relief valve open duration learned value	Reset pressure sensor offset	Calibration longitudinal acceleration sensor	RCM configuration(Beta)	Ignition key erase	Ignition key program	Erase All Remote Trasmitter	EGR System Flow Test	Program Unlimited Key Code
Mercury	EscapeTributeMarinerMarverick	2.5L	DURATEC-HE/I4	PATS(Passive Anti Theft System)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	SYSTEM SEARCH																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PCM(PowerTrain Control Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	4X4(4x4 Control Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ABS(Anti-Lock Brake System)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	ACM(Audio Control Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	APIM(Accessory Protocol Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FCIM(Front Controls Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	FDIM(Front Display Interface Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GEM/SJB(Generic Electronic Module/Smart Junction Box)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	GPSM(Global Positioning System Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	HVAC(Heating Ventilation Air Conditioning)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	IC(Instrument Cluster)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	OCSM(Occupant Classification System Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PSCM(Power Steering Control Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PAM(Parking Aid Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	RCM(Restraint Control Module)																									
Mercury	EscapeTributeMarinerMarverick	3.0L	4V	PATS(Passive Anti Theft System)																									

VEHICLE	SYSTEM 1	VEHICLE2	SYSTEM 2	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Reset of fuel injector learned value	Reset of rail pressure sensor learned value	Reset of lambda control tester learned value	Reset of air mass flow rate/intake air temperature sensor learned value	Reset of EGR valve learned value	Reset of Adblue metering device value	Reset of SCR Catalytic converter value	Reset of DPF learned value	Reset of pressure limiting valve in rail learned value	Reset of turbocharger learned value	Reset of starter learned value	Reset of differential pressure sensor of DPF learned value	Cancellation of limitation of engine starts	Commissioning	Dosing Valve Check	Injector ID Code Check	Injector ID Code Registration	Fuel Injection Stop Test	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Each Relay Check	EGR Check	Suction Air Volume Check	Fuel Check	DPF Regeneration (Manual)	DPF Related Information Reset	SCR Related Information Reset	Supply Pump Initializtion	ECU RESTART	ECU Memory Reset	A/T Communication Record Reset	Refreshing Mode for Urea Deposit	Reset of oil monitoring	Airflow Sensor No. Information Writing
International	EURO 2/3/4		Engine	V	V	V	V	V																V								V	V	V	V			V			V
International	EURO 2/3/4		Transmission	V	V	V	V	V																																		
International	EURO 2/3/4		ISS(Idling Stop and Start System)	V	V	V		V																																		
International	EURO 2/3/4		Integration Control	V	V	V		V																																		
International	EURO 2/3/4		Motor Control	V	V			V																																		
International	EURO 2/3/4		Battery Control	V	V	V		V																																		
International	EURO 2/3/4		BlueTec/SCR(Selective Catalytic Reduction)	V	V	V		V																																		
International	EURO 2/3/4		Air Suspension	V	V	V	V	V																																		
International	EURO 2/3/4		ABS	V	V	V	V	V																													V					
International	EURO 2/3/4		EZGO	V	V	V		V																														V				
International	EURO 2/3/4		MBECS(Motor vehicle Brake Energy Conservation System)	V	V	V		V																																		
International	EURO 2/3/4		Retarder	V	V	V		V																													V					
International	EURO 2/3/4		Immobilizer	V	V	V		V																																		
International	EURO 2/3/4		SRS Airbag	V	V	V		V																																		
International	EURO 2/3/4		SWS(Smart Wiring System)	V	V	V		V																																		
International	EURO 2/3/4		MDAS(Mitsubishi Driver's Attention monitoring System)	V	V	V		V																																		
International	EURO 2/3/4		Distance Warning	V	V	V		V																																		
International	EURO 2/3/4		MILS(Mitsubishi Intelligent Load monitoring System)	V	V			V																																		
International	EURO 2/3/4		Headlamp Auto-Leveling	V	V	V		V																																		
International	EURO 5	CANTER	Engine	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V											V								V	
International	EURO 5	CANTER	ISS	V	V	V	V	V																								V								V	
International	EURO 5	CANTER	Transmission	V	V	V	V	V																																		
International	EURO 5	CANTER	ABS	V	V	V		V																																		
International	EURO 5	CANTER	EZGO	V	V	V		V																																		
International	EURO 5	CANTER	SRS Airbag	V	V			V																																		
International	EURO 5	CANTER	SAM(Signal detection and Actuation Module)	V	V	V	V	V																																		
International	EURO 5	CANTER	Instrument	V	V	V	V	V																																		
International	EURO 5	CANTER	HLAL	V	V	V		V																																		
International	EURO 5	CANTER	HVAC	V	V	V	V	V																																		
International	EURO 5	CANTER	Immobilizer	V	V	V		V																																		
International	EURO 5	FIGHTER	Engine	V	V	V	V	V																V								V	V	V	V			V			V
International	EURO 5	FIGHTER	Integration Control	V	V			V																																		
International	EURO 5	FIGHTER	ABS	V	V	V	V	V																													V					
International	EURO 5	FIGHTER	SRS Airbag	V	V	V		V																																		
International	12PIN SYSTEM		Engine	V																																						

Vehicle	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	CO Adjustment(Leaded Fuel Onley)	ECM Segment	TEC Adaptation	EBCM Air Bleeding	AT(TCM) Learning Value Initialization	ISU Key Coding	VIN Write	Fault Continuation Time Check	Driver Seat SBR Setup	Passenger Seat SBR Setup	Idling RPM Check	Fuel Trim Check	DPF Recycle	Cranking RPM Check	Sub-system Combination Setup	Tire Size Setting	Steering Angle Sensor Calibration	Open/Closed Loop Check	Hydraulic System Test	TCC Solenoid Adjustment	PCS Current Adjustment	Shift Gear Command	Manual Control	Gear Tension	Return to the Motor Home Position
ESPERO	POWERTRAIN	1.8 MPI SOHC	V	V	V																			V							
ESPERO	POWERTRAIN	2.0 MPI SOHC	V	V	V																			V							
ESPERO	POWERTRAIN	1.5 MPFI DOHC	V	V	V																			V							
PRINCE	POWERTRAIN	1.8 SOHC	V	V	V																			V							
PRINCE	POWERTRAIN	2.0 SOHC	V	V	V																			V							
PRINCE	POWERTRAIN	2.2 DOHC	V	V	V																			V							
PRINCE	POWERTRAIN	V96(SIEMENS)	V	V	V	V																									
PRINCE	CHASSIS	ABS	V	V						V															V						
LANOS	POWERTRAIN	1.3 SOHC	V	V	V																										
LANOS	POWERTRAIN	1.5 SOHC	V	V	V																										
LANOS	POWERTRAIN	1.5 DOHC	V	V	V																										
LANOS	POWERTRAIN	1.6 DOHC	V	V	V																										
LANOS	POWERTRAIN	AUTO T/M	V	V	V																					V	V	V			
LANOS	AIRBAG	AIR BAG	V			V								V																	
LANOS	CHASSIS	ABS DELPHI	V	V	V																								V	V	V
LANOS	CHASSIS	ABS B0SCH	V	V	V	V				V																					
NUBIRA	POWERTRAIN	1.5 SOHC	V	V	V																										
NUBIRA	POWERTRAIN	1.5 DOHC	V	V	V																										
NUBIRA	POWERTRAIN	1.6 DOHC	V	V	V																										
NUBIRA	POWERTRAIN	1.8 DOHC	V	V	V																										
NUBIRA	POWERTRAIN	2.0 SOHC	V	V	V																										
NUBIRA	POWERTRAIN	2.0 DOHC	V	V	V																										
NUBIRA	POWERTRAIN	AUTO T/M	V	V	V																					V	V	V			
NUBIRA	BODY	AIR BAG	V	V	V																								V	V	V
NUBIRA	CHASSIS	ABS	V	V		V																									
LEGANZA	POWERTRAIN	1.8 SOHC	V	V	V																										
LEGANZA	POWERTRAIN	1.8 DOHC	V	V	V																										
LEGANZA	POWERTRAIN	2.0 SOHC	V	V	V																										
LEGANZA	POWERTRAIN	2.0 DOHC	V	V	V																										
LEGANZA	POWERTRAIN	2.2 DOHC	V	V	V																										
LEGANZA	POWERTRAIN	AUTO T/M	V	V	V	V																									
LEGANZA	BODY	AIR BAG	V	V						V															V						
LEGANZA	CHASSIS	ABS	V	V		V																									
NUBIRA II	POWERTRAIN	1.5 DOHC	V	V	V																										
NUBIRA II	POWERTRAIN	1.8/2.0	V	V	V																										
NUBIRA II	POWERTRAIN	AUTO T/M	V	V	V	V					V																				
NUBIRA II	BODY	AIR BAG	V	V	V	V				V																					
NUBIRA II	CHASSIS	ABS	V	V		V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2010	Allure	Powertrain	(C) 2.4L LAF Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																												
G	2010	Allure	Powertrain	(C) 2.4L LAF Fuel Pump Control Module	V	V																		V	V							V		V																											
G	2010	Allure	Powertrain	(C) 2.4L LAF Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
G	2010	Allure	Powertrain	(G) 3.0L LF1 Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V														
G	2010	Allure	Powertrain	(G) 3.0L LF1 Fuel Pump Control Module	V	V																		V	V							V		V																											
G	2010	Allure	Powertrain	(G) 3.0L LF1 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
G	2010	Allure	Powertrain	(V) 3.6L LLT Engine Control Module	V																			V	V						V	V	V								V	V	V	V																
G	2010	Allure	Powertrain	(V) 3.6L LLT Fuel Pump Control Module	V	V																		V	V							V		V																											
G	2010	Allure	Powertrain	(V) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V								V														
G	2010	Allure	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V													
G	2010	Allure	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V							
G	2010	Allure	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V			
G	2010	Allure	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
G	2010	Allure	Chassis	Power Steering Control Module	V	V																			V																																			
G	2010	Allure	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
G	2010	Allure	Chassis	Suspension Control Module	V	V																		V	V																																			
G	2010	Allure	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
G	2010	Allure	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
G	2010	Allure	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3	V	V																		V	V																																			
G	2010	Allure	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4	V	V																		V	V																																			
G	2010	Allure	Body	Passenger Presence Module	V	V																			V																																			
G	2010	Allure	Body	Instrument Cluster	V	V																		V	V																																			
G	2010	Allure	Body	Head-Up Display Module	V																			V	V																																			
G	2010	Allure	Body	Radio	V	V																		V	V																																			
G	2010	Allure	Body	Digital Radio Receiver Control Module	V	V																			V																																			
G	2010	Allure	Body	Multimedia Player Interface Module	V	V																			V																																			
G	2010	Allure	Body	Telematics Communication Interface Control Module Version 8	V	V																		V	V																																			
G	2010	Allure	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
G	2010	Allure	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
G	2010	Allure	Body	Seat Memory Control Module	V																																																						
G	2010	Allure	Body	Front Seat Heating Control Module	V	V																		V	V																																			
G	2010	Allure	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
G	2010	Allure	Body	Keyless Entry Control Module	V	V																		V	V																																			
G	2010	Allure	Body	Right Side Object Detection Control Module	V	V																		V	V																																			
G	2010	Allure	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
G	2010	Allure	Body	Parking Assist Control Module	V																			V	V																																			
G	2010	Allure	Body	Steering Column Lock Control Module	V	V																			V																																			
G	2010	Lacrosse	Powertrain	(C) 2.4L LAF Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																												
G	2010	Lacrosse	Powertrain	(C) 2.4L LAF Fuel Pump Control Module	V	V																		V	V							V		V																											
G	2010	Lacrosse	Powertrain	(C) 2.4L LAF Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
G	2010	Lacrosse	Powertrain	(G) 3.0L LF1 Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V														
G	2010	Lacrosse	Powertrain	(G) 3.0L LF1 Fuel Pump Control Module	V	V																		V	V							V		V																											
G	2010	Lacrosse	Powertrain	(G) 3.0L LF1 Transmission Control Module	V	V																		V	V										V	V	V	V								V													
G	2010	Lacrosse	Powertrain	(V) 3.6L LLT Engine Control Module	V																			V	V						V	V	V								V	V	V	V																
G	2010	Lacrosse	Powertrain	(V) 3.6L LLT Fuel Pump Control Module	V	V																		V	V							V		V																											
G	2010	Lacrosse	Powertrain	(V) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V								V													
G	2010	Lacrosse	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V													
G	2010	Lacrosse	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V							
G	2010	Lacrosse	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V			
G	2010	Lacrosse	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
G	2010	Lacrosse	Chassis	Power Steering Control Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2010	Lacrosse	Chassis	Steering Wheel Angle Sensor Module	V																				V																																				
G	2010	Lacrosse	Chassis	Suspension Control Module	V	V																		V	V																																			
G	2010	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
G	2010	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
G	2010	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3	V	V																		V	V																																			
G	2010	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4	V	V																		V	V																																			
G	2010	Lacrosse	Body	Passenger Presence Module	V	V																			V																																			
G	2010	Lacrosse	Body	Instrument Cluster	V	V																		V	V																																			
G	2010	Lacrosse	Body	Head-Up Display Module	V																			V	V																																			
G	2010	Lacrosse	Body	Headlamp Control Module	V	V																		V	V																																			
G	2010	Lacrosse	Body	Radio	V	V																		V	V																																			
G	2010	Lacrosse	Body	Digital Radio Receiver Control Module	V	V																			V																																			
G	2010	Lacrosse	Body	Multimedia Player Interface Module	V	V																			V																																			
G	2010	Lacrosse	Body	Telematics Communication Interface Control Module Version 8	V	V																		V	V																																			
G	2010	Lacrosse	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
G	2010	Lacrosse	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
G	2010	Lacrosse	Body	HVAC Control Module Auto Dual (CJ2)	V	V																		V	V																																			
G	2010	Lacrosse	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
G	2010	Lacrosse	Body	Seat Memory Control Module	V																																																						
G	2010	Lacrosse	Body	Front Seat Heating Control Module	V	V																		V	V																																			
G	2010	Lacrosse	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
G	2010	Lacrosse	Body	Keyless Entry Control Module	V	V																		V	V																																			
G	2010	Lacrosse	Body	Right Side Object Detection Control Module	V	V																		V	V																																			
G	2010	Lacrosse	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
G	2010	Lacrosse	Body	Parking Assist Control Module	V																			V	V																																			
G	2010	Lacrosse	Body	Steering Column Lock Control Module	V	V																			V																																			
G	2011	Lacrosse	Powertrain	(C) 2.4L LAF Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																												
G	2011	Lacrosse	Powertrain	(C) 2.4L LAF Fuel Pump Control Module	V	V																	V	V	V							V		V																									
G	2011	Lacrosse	Powertrain	(C) 2.4L LAF Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
G	2011	Lacrosse	Powertrain	(Y) 3.0L LF1 Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
G	2011	Lacrosse	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module	V	V																		V	V							V		V																									
G	2011	Lacrosse	Powertrain	(Y) 3.0L LF1 Transmission Control Module	V	V																		V	V										V	V	V	V								V													
G	2011	Lacrosse	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V						V	V	V								V	V	V	V															
G	2011	Lacrosse	Powertrain	(D) 3.6L LLT Fuel Pump Control Module	V	V																		V	V							V		V																									
G	2011	Lacrosse	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V									V													
G	2011	Lacrosse	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																							V												
G	2011	Lacrosse	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V	V						
G	2011	Lacrosse	Chassis	Parking Brake Control Module	V	V																			V																						V								V	V	V	V		
G	2011	Lacrosse	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
G	2011	Lacrosse	Chassis	Power Steering Control Module	V	V																			V																																			
G	2011	Lacrosse	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
G	2011	Lacrosse	Chassis	Suspension Control Module	V	V																		V	V																																			
G	2011	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
G	2011	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
G	2011	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3	V	V																		V	V																																			
G	2011	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4	V	V																		V	V																																			
G	2011	Lacrosse	Body	Passenger Presence Module	V	V																			V																																			
G	2011	Lacrosse	Body	Instrument Cluster	V	V																		V	V																																			
G	2011	Lacrosse	Body	Head-Up Display Module	V																			V	V																																			
G	2011	Lacrosse	Body	Headlamp Control Module	V	V																		V	V																																			
G	2011	Lacrosse	Body	Radio	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2011	Lacrosse	Body	Digital Radio Receiver Control Module	V	V																			V																																			
G	2011	Lacrosse	Body	Multimedia Player Interface Module	V	V																			V																																			
G	2011	Lacrosse	Body	Telematics Communication Interface Control Module Version 8	V	V																		V	V																																			
G	2011	Lacrosse	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
G	2011	Lacrosse	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
G	2011	Lacrosse	Body	HVAC Control Module Auto Dual (CJ2)	V	V																		V	V																																			
G	2011	Lacrosse	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
G	2011	Lacrosse	Body	Seat Memory Control Module	V																																																							
G	2011	Lacrosse	Body	Front Seat Heating Control Module	V	V																		V	V																																			
G	2011	Lacrosse	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
G	2011	Lacrosse	Body	Keyless Entry Control Module	V	V																		V	V																																			
G	2011	Lacrosse	Body	Right Side Object Detection Control Module	V	V																		V	V																																			
G	2011	Lacrosse	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
G	2011	Lacrosse	Body	Parking Assist Control Module	V																			V	V																																			
G	2011	Lacrosse	Body	Steering Column Lock Control Module	V	V																			V																																			
G	2011	Regal	Powertrain	(V) 2.0L LHU Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V	V														
G	2011	Regal	Powertrain	(V) 2.0L LHU Transmission Control Module	V	V																		V	V										V			V																						
G	2011	Regal	Powertrain	(C) 2.4L LAF Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																											
G	2011	Regal	Powertrain	(C) 2.4L LAF Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
G	2011	Regal	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																										
G	2011	Regal	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																					V														
G	2011	Regal	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V							
G	2011	Regal	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V			
G	2011	Regal	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
G	2011	Regal	Chassis	Power Steering Control Module	V	V																			V																																			
G	2011	Regal	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
G	2011	Regal	Chassis	Suspension Control Module	V	V																		V	V																																			
G	2011	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
G	2011	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
G	2011	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3	V	V																		V	V																																			
G	2011	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4	V	V																		V	V																																			
G	2011	Regal	Body	Passenger Presence Module	V	V																			V																																			
G	2011	Regal	Body	Instrument Cluster	V	V																		V	V																																			
G	2011	Regal	Body	Head-Up Display Module	V																			V	V																																			
G	2011	Regal	Body	Radio	V	V																		V	V																																			
G	2011	Regal	Body	Digital Radio Receiver Control Module	V	V																			V																																			
G	2011	Regal	Body	Multimedia Player Interface Module	V	V																			V																																			
G	2011	Regal	Body	Telematics Communication Interface Control Module Version 8	V	V																		V	V																																			
G	2011	Regal	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
G	2011	Regal	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
G	2011	Regal	Body	Remote Heater and Air Conditioning Control Module	V	V																		V	V																																			
G	2011	Regal	Body	Seat Memory Control Module	V																																																							
G	2011	Regal	Body	Front Seat Heating Control Module	V	V																		V	V																																			
G	2011	Regal	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
G	2011	Regal	Body	Keyless Entry Control Module	V	V																		V	V																																			
G	2011	Regal	Body	Right Side Object Detection Control Module	V	V																		V	V																																			
G	2011	Regal	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
G	2011	Regal	Body	Parking Assist Control Module	V																			V	V																																			
G	2011	Regal	Body	Steering Column Lock Control Module	V	V																			V																																			
G	2012	Lacrosse	Powertrain	(M) 2.4L LAF Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V															
G	2012	Lacrosse	Powertrain	(M) 2.4L LAF Fuel Pump Control Module	V	V																		V	V							V		V																										

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2012	Lacrosse	Powertrain	(M) 2.4L LAF Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
G	2012	Lacrosse	Powertrain	(R) 2.4L LUK Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V														
G	2012	Lacrosse	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																			V																																		
G	2012	Lacrosse	Powertrain	(R) 2.4L LUK Fuel Pump Control Module	V	V									V									V	V							V																											
G	2012	Lacrosse	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module	V	V	V																	V	V																																	
G	2012	Lacrosse	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
G	2012	Lacrosse	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
G	2012	Lacrosse	Powertrain	(5) 3.0L LFW Fuel Pump Control Module	V	V																		V	V							V		V																								
G	2012	Lacrosse	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
G	2012	Lacrosse	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
G	2012	Lacrosse	Powertrain	(3) 3.6L LFX Fuel Pump Control Module	V	V																		V	V							V		V																								
G	2012	Lacrosse	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V												
G	2012	Lacrosse	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V												
G	2012	Lacrosse	Chassis	Electronic Brake Control Module	V																																																					
G	2012	Lacrosse	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
G	2012	Lacrosse	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
G	2012	Lacrosse	Chassis	Power Steering Control Module	V	V																			V																																	
G	2012	Lacrosse	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
G	2012	Lacrosse	Chassis	Suspension Control Module	V	V																		V	V																																	
G	2012	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																	
G	2012	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																	
G	2012	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3	V	V																		V	V																																	
G	2012	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4	V	V																		V	V																																	
G	2012	Lacrosse	Body	Passenger Presence Module	V	V																			V																																	
G	2012	Lacrosse	Body	Instrument Cluster	V	V																		V	V																																	
G	2012	Lacrosse	Body	Head-Up Display Module	V																			V	V																																	
G	2012	Lacrosse	Body	Headlamp Control Module	V	V																		V	V																																	
G	2012	Lacrosse	Body	Radio	V	V																		V	V																																	
G	2012	Lacrosse	Body	Digital Radio Receiver Control Module	V	V																			V																																	
G	2012	Lacrosse	Body	Multimedia Player Interface Module	V	V																			V																																	
G	2012	Lacrosse	Body	Telematics Communication Interface Control Module Version 8	V	V																		V	V																																	
G	2012	Lacrosse	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
G	2012	Lacrosse	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
G	2012	Lacrosse	Body	HVAC Control Module Auto Dual (CJ2)	V	V																		V	V																																	
G	2012	Lacrosse	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																	
G	2012	Lacrosse	Body	Seat Memory Control Module	V																																																				
G	2012	Lacrosse	Body	Front Seat Heating Control Module	V	V																		V	V																																	
G	2012	Lacrosse	Body	Rear Seat Heating Control Module	V	V																		V	V																																	
G	2012	Lacrosse	Body	Keyless Entry Control Module	V	V																		V	V																																	
G	2012	Lacrosse	Body	Right Side Object Detection Control Module	V	V																		V	V																																	
G	2012	Lacrosse	Body	Left Side Object Detection Control Module	V	V																		V	V																																	
G	2012	Lacrosse	Body	Parking Assist Control Module	V																			V	V																																	
G	2012	Lacrosse	Body	Steering Column Lock Control Module	V	V																			V																																	
G	2012	Lacrosse	Body	Battery Energy Control Module		V																			V																																	
G	2012	Regal	Powertrain	(V) 2.0L LHU Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V	V													
G	2012	Regal	Powertrain	(V) 2.0L LHU Transmission Control Module T76 (MHK)	V	V																		V	V									V	V	V	V	V	V																			
G	2012	Regal	Powertrain	(V) 2.0L LHU Transmission Control Module AF40 Gen II (MDK)	V	V																		V	V									V			V																					
G	2012	Regal	Powertrain	2.0L LTD Engine Control Module	V																			V	V				V	V	V	V													V													
G	2012	Regal	Powertrain	2.0L LTD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
G	2012	Regal	Powertrain	(K) 2.4L LEA Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																									
G	2012	Regal	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2012	Regal	Powertrain	(R) 2.4L LUK Engine Control Module	V																			V	V	V	V		V	V	V	V	V													V																
G	2012	Regal	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																			V																																					
G	2012	Regal	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module	V	V	V																	V	V																																				
G	2012	Regal	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
G	2012	Regal	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																											
G	2012	Regal	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V													
G	2012	Regal	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V							
G	2012	Regal	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
G	2012	Regal	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
G	2012	Regal	Chassis	Power Steering Control Module	V	V																			V																																			
G	2012	Regal	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
G	2012	Regal	Chassis	Suspension Control Module	V	V																		V	V																																			
G	2012	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
G	2012	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
G	2012	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3	V	V																		V	V																																			
G	2012	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4	V	V																		V	V																																			
G	2012	Regal	Body	Passenger Presence Module	V	V																			V																																			
G	2012	Regal	Body	Instrument Cluster	V	V																		V	V																																			
G	2012	Regal	Body	Head-Up Display Module	V																			V	V																																			
G	2012	Regal	Body	Radio	V	V																		V	V																																			
G	2012	Regal	Body	Digital Radio Receiver Control Module	V	V																			V																																			
G	2012	Regal	Body	Multimedia Player Interface Module	V	V																			V																																			
G	2012	Regal	Body	Telematics Communication Interface Control Module Version 8	V	V																		V	V																																			
G	2012	Regal	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
G	2012	Regal	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
G	2012	Regal	Body	Remote Heater and Air Conditioning Control Module	V	V																		V	V																																			
G	2012	Regal	Body	Seat Memory Control Module	V																																																							
G	2012	Regal	Body	Front Seat Heating Control Module	V	V																		V	V																																			
G	2012	Regal	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
G	2012	Regal	Body	Keyless Entry Control Module	V	V																		V	V																																			
G	2012	Regal	Body	Right Side Object Detection Control Module	V	V																		V	V																																			
G	2012	Regal	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
G	2012	Regal	Body	Parking Assist Control Module	V																			V	V																																			
G	2012	Regal	Body	Steering Column Lock Control Module	V	V																			V																																			
G	2012	Regal	Body	Battery Energy Control Module		V																			V																																			
G	2013	Lacrosse	Powertrain	(R) 2.4L LUK Engine Control Module	V																			V	V	V	V		V	V	V	V	V													V																
G	2013	Lacrosse	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																			V																																				
G	2013	Lacrosse	Powertrain	(R) 2.4L LUK Fuel Pump Control Module	V	V									V									V	V							V																												
G	2013	Lacrosse	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module	V	V	V																	V	V																																			
G	2013	Lacrosse	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
G	2013	Lacrosse	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V														
G	2013	Lacrosse	Powertrain	(3) 3.6L LFX Fuel Injector Control Module	V	V									V					V				V	V																																			
G	2013	Lacrosse	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V													
G	2013	Lacrosse	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V													
G	2013	Lacrosse	Chassis	Electronic Brake Control Module	V																																																						
G	2013	Lacrosse	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
G	2013	Lacrosse	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
G	2013	Lacrosse	Chassis	Power Steering Control Module	V	V																			V																																			
G	2013	Lacrosse	Chassis	Power Steering Control Module	V	V																			V																																			
G	2013	Lacrosse	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
G	2013	Lacrosse	Chassis	Suspension Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2013	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
G	2013	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
G	2013	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
G	2013	Lacrosse	Body	Passenger Presence Module	V	V																			V																																			
G	2013	Lacrosse	Body	Instrument Cluster	V	V																		V	V																																			
G	2013	Lacrosse	Body	Head-Up Display Module	V																			V	V																																			
G	2013	Lacrosse	Body	Headlamp Control Module	V	V																		V	V																																			
G	2013	Lacrosse	Body	Radio	V	V																		V	V																																			
G	2013	Lacrosse	Body	Rear Audio Control Module	V	V																		V	V																																			
G	2013	Lacrosse	Body	Multimedia Player Interface Module	V	V																			V																																			
G	2013	Lacrosse	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
G	2013	Lacrosse	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
G	2013	Lacrosse	Body	HVAC Control Module	V	V																		V	V																																			
G	2013	Lacrosse	Body	Seat Memory Control Module	V																																																							
G	2013	Lacrosse	Body	Front Seat Heating Control Module	V	V																		V	V																																			
G	2013	Lacrosse	Body	Keyless Entry Control Module	V	V																		V	V																																			
G	2013	Lacrosse	Body	Right Side Object Detection Control Module	V	V																		V	V																																			
G	2013	Lacrosse	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
G	2013	Lacrosse	Body	Parking Assist Control Module	V																			V	V																																			
G	2013	Lacrosse	Body	Steering Column Lock Control Module	V	V																			V																																			
G	2013	Lacrosse	Body	Battery Energy Control Module		V																			V																																			
G	2013	Regal	Powertrain	(V) 2.0L LHU Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V														
G	2013	Regal	Powertrain	(V) 2.0L LHU Transmission Control Module T76 (MHK)	V	V																		V	V									V	V	V	V	V	V																			
G	2013	Regal	Powertrain	(V) 2.0L LHU Transmission Control Module AF40 Gen II (MDK)	V	V																		V	V									V			V																						
G	2013	Regal	Powertrain	(R) 2.4L LUK Engine Control Module	V																			V	V	V	V		V	V	V	V	V											V														
G	2013	Regal	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																			V																																		
G	2013	Regal	Powertrain	(R) 2.4L LUK Fuel Pump Control Module	V	V																		V	V							V		V																									
G	2013	Regal	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module	V	V	V																	V	V																																		
G	2013	Regal	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
G	2013	Regal	Powertrain	Fuel Injector Control Module	V	V								V						V				V	V																																		
G	2013	Regal	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V											
G	2013	Regal	Chassis	Electronic Brake Control Module	V																																																					
G	2013	Regal	Chassis	Parking Brake Control Module	V	V																			V																						V						V	V	V	V		
G	2013	Regal	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
G	2013	Regal	Chassis	Power Steering Control Module	V	V																			V																																		
G	2013	Regal	Chassis	Power Steering Control Module	V	V																			V																																		
G	2013	Regal	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
G	2013	Regal	Chassis	Suspension Control Module	V	V																		V	V																																		
G	2013	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
G	2013	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
G	2013	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
G	2013	Regal	Body	Passenger Presence Module	V	V																			V																																			
G	2013	Regal	Body	Instrument Cluster	V	V																		V	V																																			
G	2013	Regal	Body	Radio	V	V																		V	V																																			
G	2013	Regal	Body	Multimedia Player Interface Module	V	V																			V																																			
G	2013	Regal	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
G	2013	Regal	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
G	2013	Regal	Body	HVAC Control Module	V	V																		V	V																																			
G	2013	Regal	Body	Front Seat Heating Control Module	V	V																		V	V																																			
G	2013	Regal	Body	Keyless Entry Control Module	V	V																		V	V																																			
G	2013	Regal	Body	Parking Assist Control Module	V																			V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2013	Regal	Body	Steering Column Lock Control Module	V	V																			V																																			
G	2013	Regal	Body	Battery Energy Control Module		V																			V																																			
G	2014	Lacrosse	Powertrain	(R) 2.4L LUK Engine Control Module	V																			V	V	V	V		V	V	V	V	V													V														
G	2014	Lacrosse	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																			V																																			
G	2014	Lacrosse	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module	V	V	V																	V	V																																		
G	2014	Lacrosse	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
G	2014	Lacrosse	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V			V													
G	2014	Lacrosse	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V													
G	2014	Lacrosse	Powertrain	Chassis Control Module	V	V									V									V	V							V																											
G	2014	Lacrosse	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V											
G	2014	Lacrosse	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V					
G	2014	Lacrosse	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
G	2014	Lacrosse	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
G	2014	Lacrosse	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		
G	2014	Lacrosse	Chassis	Power Steering Control Module	V	V																			V																																		
G	2014	Lacrosse	Chassis	Power Steering Control Module	V	V																			V																																		
G	2014	Lacrosse	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
G	2014	Lacrosse	Chassis	Suspension Control Module	V	V																		V	V																																		
G	2014	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																		
G	2014	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
G	2014	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
G	2014	Lacrosse	Body	Passenger Presence Module	V	V																			V																																		
G	2014	Lacrosse	Body	Instrument Cluster	V	V																		V	V																																		
G	2014	Lacrosse	Body	Head-Up Display Module	V																			V	V																																		
G	2014	Lacrosse	Body	Radio Controls	V																				V																																		
G	2014	Lacrosse	Body	HVAC Controls	V																			V	V																																		
G	2014	Lacrosse	Body	Headlamp Control Module	V	V																		V	V																																		
G	2014	Lacrosse	Body	Radio	V	V																		V	V																																		
G	2014	Lacrosse	Body	Amplifier	V	V																			V																																		
G	2014	Lacrosse	Body	Media Disc Player	V	V																		V	V																																		
G	2014	Lacrosse	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
G	2014	Lacrosse	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
G	2014	Lacrosse	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
G	2014	Lacrosse	Body	HVAC Control Module	V	V																		V	V																																		
G	2014	Lacrosse	Body	Seat Memory Control Module - Driver	V																																																					
G	2014	Lacrosse	Body	Keyless Entry Control Module	V	V																		V	V																																		
G	2014	Lacrosse	Body	Left Side Object Detection Control Module	V																			V	V																																		
G	2014	Lacrosse	Body	Parking Assist Control Module	V																			V	V																																		
G	2014	Lacrosse	Body	Frontview Camera Module	V	V																		V	V																																		
G	2014	Lacrosse	Body	Battery Energy Control Module		V																			V																																		
G	2014	Regal	Powertrain	(X) 2.0L LTG Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V	V														
G	2014	Regal	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																		V	V									V	V	V	V									V													
G	2014	Regal	Powertrain	(K) 2.4L LEA Engine Control Module	V																			V	V	V	V	V	V	V	V	V	V																										
G	2014	Regal	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
G	2014	Regal	Powertrain	(R) 2.4L LUK Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V	V														
G	2014	Regal	Powertrain	(R) 2.4L LUK Chassis Control Module	V	V																		V	V							V		V																									
G	2014	Regal	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																			V																																		
G	2014	Regal	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module	V	V	V																	V	V																																		
G	2014	Regal	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																		V	V									V	V	V	V									V													
G	2014	Regal	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V											
G	2014	Regal	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2014	Regal	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																				
G	2014	Regal	Chassis	Parking Brake Control Module	V	V																			V																						V						V	V	V	V		
G	2014	Regal	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
G	2014	Regal	Chassis	Power Steering Control Module TRW Belt Drive - Global A EPS	V	V																			V																																			
G	2014	Regal	Chassis	Power Steering Control Module PSCM - Global A - EPS	V	V																			V																																			
G	2014	Regal	Chassis	Power Steering Control Module PSCM - Global A - VES	V	V																			V																																			
G	2014	Regal	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
G	2014	Regal	Chassis	Suspension Control Module	V	V																		V	V																																			
G	2014	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
G	2014	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
G	2014	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
G	2014	Regal	Body	Passenger Presence Module	V	V																			V																																				
G	2014	Regal	Body	Instrument Cluster	V	V																		V	V																																			
G	2014	Regal	Body	Radio Controls	V																				V																																			
G	2014	Regal	Body	HVAC Controls	V																			V	V																																			
G	2014	Regal	Body	Radio	V	V																		V	V																																			
G	2014	Regal	Body	Amplifier	V	V																			V																																			
G	2014	Regal	Body	Human Machine Interface Control Module	V	V																		V	V																						V													
G	2014	Regal	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
G	2014	Regal	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
G	2014	Regal	Body	HVAC Control Module	V	V																		V	V																																			
G	2014	Regal	Body	Seat Memory Control Module - Driver	V																				V																																			
G	2014	Regal	Body	Front Seat Heating Control Module	V	V																		V	V																																			
G	2014	Regal	Body	Keyless Entry Control Module	V	V																		V	V																																			
G	2014	Regal	Body	Left Side Object Detection Control Module	V																			V	V																																			
G	2014	Regal	Body	Parking Assist Control Module	V																			V	V																																			
G	2014	Regal	Body	Frontview Camera Module	V	V																		V	V																																			
G	2014	Regal	Body	Battery Energy Control Module		V																			V																																			
G	2015	Lacrosse	Powertrain	(R) 2.4L LUK Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V														
G	2015	Lacrosse	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																			V																																			
G	2015	Lacrosse	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module	V	V	V																	V	V																																			
G	2015	Lacrosse	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
G	2015	Lacrosse	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V													
G	2015	Lacrosse	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V												
G	2015	Lacrosse	Powertrain	Chassis Control Module	V	V									V									V	V							V																											
G	2015	Lacrosse	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																							V											
G	2015	Lacrosse	Chassis	Electronic Brake Control Module	V	V																		V	V												V												V	V	V	V	V	V						
G	2015	Lacrosse	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
G	2015	Lacrosse	Chassis	Parking Brake Control Module	V	V																			V																						V						V	V	V	V		
G	2015	Lacrosse	Chassis	Power Steering Control Module	V	V																			V																																			
G	2015	Lacrosse	Chassis	Power Steering Control Module	V	V																			V																																			
G	2015	Lacrosse	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
G	2015	Lacrosse	Chassis	Suspension Control Module	V	V																		V	V																																			
G	2015	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
G	2015	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
G	2015	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
G	2015	Lacrosse	Body	Passenger Presence Module	V	V																			V																																			
G	2015	Lacrosse	Body	Instrument Cluster	V	V																		V	V																																			
G	2015	Lacrosse	Body	Head-Up Display Module	V																			V	V																																			
G	2015	Lacrosse	Body	Radio Controls	V																				V																																			
G	2015	Lacrosse	Body	HVAC Controls	V																			V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2015	Lacrosse	Body	Headlamp Control Module	V	V																		V	V																																			
G	2015	Lacrosse	Body	Radio	V	V																		V	V																																			
G	2015	Lacrosse	Body	Amplifier	V	V																			V																																			
G	2015	Lacrosse	Body	Media Disc Player	V	V																		V	V																																			
G	2015	Lacrosse	Body	Human Machine Interface Control Module	V	V																		V	V																						V													
G	2015	Lacrosse	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
G	2015	Lacrosse	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
G	2015	Lacrosse	Body	HVAC Control Module	V	V																		V	V																																			
G	2015	Lacrosse	Body	Seat Memory Control Module - Driver	V																																																							
G	2015	Lacrosse	Body	Keyless Entry Control Module	V	V																		V	V																																			
G	2015	Lacrosse	Body	Left Side Object Detection Control Module	V																			V	V																																			
G	2015	Lacrosse	Body	Parking Assist Control Module	V																			V	V																																			
G	2015	Lacrosse	Body	Frontview Camera Module	V	V																		V	V																																			
G	2015	Lacrosse	Body	Battery Energy Control Module		V																			V																																			
G	2015	Regal	Powertrain	(X) 2.0L LTG Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V	V													
G	2015	Regal	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																		V	V										V	V	V	V									V												
G	2015	Regal	Powertrain	(K) 2.4L LEA Engine Control Module	V																			V	V	V	V	V	V	V	V	V	V																										
G	2015	Regal	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
G	2015	Regal	Powertrain	(R) 2.4L LUK Engine Control Module	V																			V	V	V	V		V	V	V	V	V													V													
G	2015	Regal	Powertrain	(R) 2.4L LUK Chassis Control Module	V	V																		V	V							V		V																								
G	2015	Regal	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																			V																																		
G	2015	Regal	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module	V	V	V																	V	V																																		
G	2015	Regal	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
G	2015	Regal	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V											
G	2015	Regal	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V	V					
G	2015	Regal	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
G	2015	Regal	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
G	2015	Regal	Chassis	Power Steering Control Module	V	V																			V																																		
G	2015	Regal	Chassis	Power Steering Control Module	V	V																			V																																		
G	2015	Regal	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
G	2015	Regal	Chassis	Suspension Control Module	V	V																		V	V																																		
G	2015	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																		
G	2015	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
G	2015	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
G	2015	Regal	Body	Passenger Presence Module	V	V																			V																																		
G	2015	Regal	Body	Instrument Cluster	V	V																		V	V																																		
G	2015	Regal	Body	Radio Controls	V																				V																																		
G	2015	Regal	Body	HVAC Controls	V																			V	V																																		
G	2015	Regal	Body	Radio	V	V																		V	V																																		
G	2015	Regal	Body	Amplifier	V	V																			V																																		
G	2015	Regal	Body	Human Machine Interface Control Module	V	V																		V	V																						V													
G	2015	Regal	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
G	2015	Regal	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
G	2015	Regal	Body	HVAC Control Module	V	V																		V	V																																			
G	2015	Regal	Body	Seat Memory Control Module - Driver	V																																																						
G	2015	Regal	Body	Front Seat Heating Control Module	V	V																		V	V																																			
G	2015	Regal	Body	Keyless Entry Control Module	V	V																		V	V																																			
G	2015	Regal	Body	Left Side Object Detection Control Module	V																			V	V																																			
G	2015	Regal	Body	Parking Assist Control Module	V																			V	V																																			
G	2015	Regal	Body	Frontview Camera Module	V	V																		V	V																																			
G	2015	Regal	Body	Battery Energy Control Module		V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2016	Lacrosse	Powertrain	(R) 2.4L LUK Engine Control Module	V																		V	V	V	V		V	V	V	V	V													V															
G	2016	Lacrosse	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																		V																																			
G	2016	Lacrosse	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module	V	V	V																V	V																																		
G	2016	Lacrosse	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
G	2016	Lacrosse	Powertrain	(3) 3.6L LFX Engine Control Module	V																		V	V				V	V	V	V	V								V	V	V	V		V													
G	2016	Lacrosse	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																	V	V										V	V	V	V									V													
G	2016	Lacrosse	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V					
G	2016	Lacrosse	Chassis	Distance Sensing Cruise Control Module	V	V																		V																																		
G	2016	Lacrosse	Chassis	Parking Brake Control Module	V	V																		V																					V								V	V	V	V		
G	2016	Lacrosse	Chassis	Power Steering Control Module	V	V																		V																																		
G	2016	Lacrosse	Chassis	Power Steering Control Module	V	V																		V																																		
G	2016	Lacrosse	Chassis	Steering Wheel Angle Sensor Module	V																			V																																		
G	2016	Lacrosse	Chassis	Suspension Control Module	V	V																	V	V																																		
G	2016	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																	V	V																																		
G	2016	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																	V	V																																		
G	2016	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
G	2016	Lacrosse	Body	Passenger Presence Module	V	V																		V																																		
G	2016	Lacrosse	Body	Instrument Cluster	V	V																	V	V																																		
G	2016	Lacrosse	Body	Head-Up Display Module	V																		V	V																																		
G	2016	Lacrosse	Body	Radio Controls	V																			V																																		
G	2016	Lacrosse	Body	HVAC Controls	V																		V	V																																		
G	2016	Lacrosse	Body	Headlamp Control Module	V	V																	V	V																																		
G	2016	Lacrosse	Body	Radio	V	V																	V	V																																		
G	2016	Lacrosse	Body	Amplifier	V	V																		V																																		
G	2016	Lacrosse	Body	Rear Audio Control Module	V	V																	V	V																																		
G	2016	Lacrosse	Body	Media Disc Player	V	V																	V	V																																		
G	2016	Lacrosse	Body	Infotainment Control Touchpad	V	V																		V																																		
G	2016	Lacrosse	Body	Human Machine Interface Control Module	V	V																	V	V																						V													
G	2016	Lacrosse	Body	Telematics Communication Interface Control Module Version 9.7	V	V																	V	V																																		
G	2016	Lacrosse	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																		
G	2016	Lacrosse	Body	HVAC Control Module	V	V																	V	V																																		
G	2016	Lacrosse	Body	Seat Memory Control Module - Driver	V																																																				
G	2016	Lacrosse	Body	Keyless Entry Control Module	V	V																	V	V																																		
G	2016	Lacrosse	Body	Left Side Object Detection Control Module	V																		V	V																																		
G	2016	Lacrosse	Body	Parking Assist Control Module	V																		V	V																																		
G	2016	Lacrosse	Body	Frontview Camera Module	V	V																	V	V																																		
G	2016	Lacrosse	Body	Battery Energy Control Module		V																		V																																		
G	2016	Regal	Powertrain	(X) 2.0L LTG Engine Control Module	V																		V	V	V	V		V	V	V	V	V												V	V													
G	2016	Regal	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																	V	V										V	V	V	V									V													
G	2016	Regal	Powertrain	(K) 2.4L LEA Engine Control Module	V																		V	V	V	V	V	V	V	V	V	V																										
G	2016	Regal	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
G	2016	Regal	Powertrain	(R) 2.4L LUK Engine Control Module	V																		V	V	V	V		V	V	V	V	V												V														
G	2016	Regal	Powertrain	(R) 2.4L LUK Chassis Control Module	V	V																	V	V								V		V																							
G	2016	Regal	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																		V																																		
G	2016	Regal	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module	V	V	V																V	V																																		
G	2016	Regal	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
G	2016	Regal	Powertrain	Rear Differential Clutch Control Module	V	V																	V	V																						V													
G	2016	Regal	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V					
G	2016	Regal	Chassis	Distance Sensing Cruise Control Module	V	V																		V																																		
G	2016	Regal	Chassis	Parking Brake Control Module	V	V																		V																						V								V	V	V	V		
G	2016	Regal	Chassis	Power Steering Control Module	V	V																		V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2016	Regal	Chassis	Power Steering Control Module	V	V																			V																																			
G	2016	Regal	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
G	2016	Regal	Chassis	Suspension Control Module	V	V																		V	V																																			
G	2016	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
G	2016	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
G	2016	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
G	2016	Regal	Body	Passenger Presence Module	V	V																			V																																			
G	2016	Regal	Body	Instrument Cluster	V	V																		V	V																																			
G	2016	Regal	Body	Radio Controls	V																				V																																			
G	2016	Regal	Body	HVAC Controls	V																			V	V																																			
G	2016	Regal	Body	Radio	V	V																		V	V																																			
G	2016	Regal	Body	Amplifier	V	V																			V																																			
G	2016	Regal	Body	Infotainment Control Touchpad	V	V																			V																																			
G	2016	Regal	Body	Human Machine Interface Control Module	V	V																		V	V																								V											
G	2016	Regal	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
G	2016	Regal	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
G	2016	Regal	Body	HVAC Control Module	V	V																		V	V																																			
G	2016	Regal	Body	Seat Memory Control Module - Driver	V																																																							
G	2016	Regal	Body	Front Seat Heating Control Module	V	V																		V	V																																			
G	2016	Regal	Body	Keyless Entry Control Module	V	V																		V	V																																			
G	2016	Regal	Body	Left Side Object Detection Control Module	V																			V	V																																			
G	2016	Regal	Body	Parking Assist Control Module	V																			V	V																																			
G	2016	Regal	Body	Frontview Camera Module	V	V																		V	V																																			
G	2016	Regal	Body	Battery Energy Control Module		V																			V																																			
P	2012	Verano	Powertrain	(K) 2.4L LEA Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V															
P	2012	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
P	2012	Verano	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																										
P	2012	Verano	Chassis	Electronic Brake Control Module	V	V																		V	V													V											V	V	V	V	V	V	V					
P	2012	Verano	Chassis	Parking Brake Control Module	V	V																			V																						V								V	V	V	V		
P	2012	Verano	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
P	2012	Verano	Chassis	Power Steering Control Module	V	V																			V																																			
P	2012	Verano	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
P	2012	Verano	Body	Body Control Module	V	V																		V	V																																			
P	2012	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
P	2012	Verano	Body	Passenger Presence Module	V	V																			V																																			
P	2012	Verano	Body	Instrument Cluster	V	V																		V	V																																			
P	2012	Verano	Body	Headlamp Control Module	V	V																		V	V																								V											
P	2012	Verano	Body	Radio	V	V																		V	V																																			
P	2012	Verano	Body	Telematics Communication Interface Control Module Version 8	V	V																		V	V																																			
P	2012	Verano	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
P	2012	Verano	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
P	2012	Verano	Body	HVAC Control Module Auto Dual (CJ2)	V	V																		V	V																																			
P	2012	Verano	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
P	2012	Verano	Body	Front Seat Heating Control Module	V	V																		V	V																																			
P	2012	Verano	Body	Keyless Entry Control Module	V	V																		V	V																																			
P	2012	Verano	Body	Parking Assist Control Module	V																			V	V																																			
P	2013	Verano	Powertrain	(V) 2.0L LHU Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V													V															
P	2013	Verano	Powertrain	(V) 2.0L LHU Engine Control Module Manual Transmission	V																			V	V	V	V		V	V	V	V													V	V														
P	2013	Verano	Powertrain	(V) 2.0L LHU Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
P	2013	Verano	Powertrain	(K) 2.4L LEA Engine Control Module	V																			V	V	V	V	V	V	V	V	V	V																												
P	2013	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2013	Verano	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																										
P	2013	Verano	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V						V
P	2013	Verano	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
P	2013	Verano	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																															V	V
P	2013	Verano	Chassis	Power Steering Control Module	V	V																			V																																	
P	2013	Verano	Chassis	Power Steering Control Module	V	V																			V																																	
P	2013	Verano	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
P	2013	Verano	Body	Body Control Module	V	V																		V	V																																	
P	2013	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
P	2013	Verano	Body	Passenger Presence Module	V	V																			V																																	
P	2013	Verano	Body	Instrument Cluster	V	V																		V	V																																	
P	2013	Verano	Body	Radio	V	V																		V	V																																	
P	2013	Verano	Body	Multimedia Player Interface Module	V	V																			V																																	
P	2013	Verano	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
P	2013	Verano	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
P	2013	Verano	Body	HVAC Control Module Auto Dual (CJ2)	V	V																		V	V																																	
P	2013	Verano	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																	
P	2013	Verano	Body	Front Seat Heating Control Module	V	V																		V	V																																	
P	2013	Verano	Body	Keyless Entry Control Module	V	V																		V	V																																	
P	2013	Verano	Body	Right Side Object Detection Control Module	V																			V	V																																	
P	2013	Verano	Body	Left Side Object Detection Control Module	V																			V	V																																	
P	2013	Verano	Body	Parking Assist Control Module	V																			V	V																																	
P	2014	Verano	Powertrain	(V) 2.0L LHU Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V													V													
P	2014	Verano	Powertrain	(V) 2.0L LHU Engine Control Module Manual Transmission	V																			V	V	V	V		V	V	V	V													V	V													
P	2014	Verano	Powertrain	(V) 2.0L LHU Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2014	Verano	Powertrain	(K) 2.4L LEA Engine Control Module	V																			V	V	V	V	V	V	V	V	V	V																									
P	2014	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2014	Verano	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																									
P	2014	Verano	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V					
P	2014	Verano	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
P	2014	Verano	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
P	2014	Verano	Chassis	Power Steering Control Module	V	V																			V																																	
P	2014	Verano	Chassis	Power Steering Control Module	V	V																			V																																	
P	2014	Verano	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
P	2014	Verano	Body	Body Control Module	V	V																		V	V																																	
P	2014	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
P	2014	Verano	Body	Passenger Presence Module	V	V																			V																																	
P	2014	Verano	Body	Instrument Cluster	V	V																		V	V																																	
P	2014	Verano	Body	Radio	V	V																		V	V																																	
P	2014	Verano	Body	Multimedia Player Interface Module	V	V																			V																																	
P	2014	Verano	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
P	2014	Verano	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
P	2014	Verano	Body	HVAC Control Module Auto Dual (CJ2)	V	V																		V	V																																	
P	2014	Verano	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																	
P	2014	Verano	Body	Front Seat Heating Control Module	V	V																		V	V																																	
P	2014	Verano	Body	Keyless Entry Control Module	V	V																		V	V																																	
P	2014	Verano	Body	Left Side Object Detection Control Module	V																			V	V																																	
P	2014	Verano	Body	Parking Assist Control Module	V																			V	V																																	
P	2014	Verano	Body	Frontview Camera Module	V	V																		V	V																																	
P	2015	Verano	Powertrain	(V) 2.0L LHU Engine Control Module	V																			V	V	V	V		V	V	V	V	V											V	V													
P	2015	Verano	Powertrain	(V) 2.0L LHU Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2015	Verano	Powertrain	(K) 2.4L LEA Engine Control Module	V																		V	V	V	V	V	V	V	V	V																														
P	2015	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																				
P	2015	Verano	Powertrain	Chassis Control Module	V	V																	V	V							V		V																											
P	2015	Verano	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V						V
P	2015	Verano	Chassis	Parking Brake Control Module	V	V																		V																					V							V	V	V	V		
P	2015	Verano	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																															V	V
P	2015	Verano	Chassis	Power Steering Control Module	V	V																		V																																	
P	2015	Verano	Chassis	Power Steering Control Module	V	V																		V																																	
P	2015	Verano	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
P	2015	Verano	Body	Body Control Module	V	V																	V	V																																	
P	2015	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																	
P	2015	Verano	Body	Passenger Presence Module	V	V																		V																																	
P	2015	Verano	Body	Instrument Cluster	V	V																	V	V																																	
P	2015	Verano	Body	Radio	V	V																	V	V																																	
P	2015	Verano	Body	Multimedia Player Interface Module	V	V																		V																																	
P	2015	Verano	Body	Telematics Communication Interface Control Module Version 9.7	V	V																	V	V																																	
P	2015	Verano	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																	
P	2015	Verano	Body	HVAC Control Module Auto Dual (CJ2)	V	V																	V	V																																	
P	2015	Verano	Body	HVAC Control Module Manual Single (C67)	V	V																	V	V																																	
P	2015	Verano	Body	Front Seat Heating Control Module	V	V																	V	V																																	
P	2015	Verano	Body	Keyless Entry Control Module	V	V																	V	V																																	
P	2015	Verano	Body	Right Side Object Detection Control Module	V																		V	V																																	
P	2015	Verano	Body	Left Side Object Detection Control Module	V																		V	V																																	
P	2015	Verano	Body	Parking Assist Control Module	V																		V	V																																	
P	2015	Verano	Body	Frontview Camera Module	V	V																	V	V																																	
P	2016	Verano	Powertrain	2.0L LHU Engine Control Module Automatic Transmission	V																		V	V	V	V		V	V	V	V	V													V													
P	2016	Verano	Powertrain	2.0L LHU Engine Control Module Manual Transmission	V																		V	V	V	V		V	V	V	V													V	V													
P	2016	Verano	Powertrain	2.0L LHU Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
P	2016	Verano	Powertrain	(K) 2.4L LEA Engine Control Module	V																		V	V	V	V	V	V	V	V	V	V																											
P	2016	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
P	2016	Verano	Powertrain	Chassis Control Module	V	V																	V	V							V		V																									
P	2016	Verano	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V						V
P	2016	Verano	Chassis	Parking Brake Control Module	V	V																		V																					V							V	V	V	V		
P	2016	Verano	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																															V	V
P	2016	Verano	Chassis	Power Steering Control Module	V	V																		V																																	
P	2016	Verano	Chassis	Power Steering Control Module	V	V																		V																																	
P	2016	Verano	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
P	2016	Verano	Body	Body Control Module	V	V																	V	V																																	
P	2016	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																	
P	2016	Verano	Body	Passenger Presence Module	V	V																		V																																	
P	2016	Verano	Body	Instrument Cluster	V	V																	V	V																																	
P	2016	Verano	Body	Radio	V	V																	V	V																																	
P	2016	Verano	Body	Multimedia Player Interface Module	V	V																		V																																	
P	2016	Verano	Body	Telematics Communication Interface Control Module Version 9.7	V	V																	V	V																																	
P	2016	Verano	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																	
P	2016	Verano	Body	HVAC Control Module Auto Dual (CJ2)	V	V																	V	V																																	
P	2016	Verano	Body	HVAC Control Module Manual Single (C67)	V	V																	V	V																																	
P	2016	Verano	Body	Front Seat Heating Control Module	V	V																	V	V																																	
P	2016	Verano	Body	Keyless Entry Control Module	V	V																	V	V																																	
P	2016	Verano	Body	Right Side Object Detection Control Module	V																		V	V																																	
P	2016	Verano	Body	Left Side Object Detection Control Module	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2016	Verano	Body	Parking Assist Control Module	V																			V	V																																				
P	2016	Verano	Body	Frontview Camera Module	V	V																		V	V																																				
W	2016	Cascada	Powertrain	(5) 1.6L LWC Engine Control Module	V																			V	V				V	V	V	V	V												V	V														
W	2016	Cascada	Powertrain	(5) 1.6L LWC Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
W	2016	Cascada	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V							V
W	2016	Cascada	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
W	2016	Cascada	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
W	2016	Cascada	Chassis	Power Steering Control Module	V	V																			V																																			
W	2016	Cascada	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
W	2016	Cascada	Body	Body Control Module	V	V																		V	V																																			
W	2016	Cascada	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
W	2016	Cascada	Body	Passenger Presence Module	V	V																			V																																			
W	2016	Cascada	Body	Instrument Cluster	V	V																		V	V																																			
W	2016	Cascada	Body	Headlamp Control Module	V	V																		V	V																					V														
W	2016	Cascada	Body	Radio	V	V																		V	V																																			
W	2016	Cascada	Body	Multimedia Player Interface Module	V	V																			V																																			
W	2016	Cascada	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
W	2016	Cascada	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
W	2016	Cascada	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																			
W	2016	Cascada	Body	HVAC Auto Control Single Zone (C68)	V	V																		V	V																																			
W	2016	Cascada	Body	Front Seat Heating Control Module	V	V																		V	V																																			
W	2016	Cascada	Body	Folding Top Control Module	V	V																		V	V																																			
W	2016	Cascada	Body	Parking Assist Control Module	V	V																		V	V																																			
W	2016	Cascada	Body	Frontview Camera Module	V	V																		V	V																																			
W	2016	Cascada	Body	Power Supply Transformer	V																				V																																			

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2010	Allure	Powertrain	(C) 2.4L LAF Engine Control Module																																																									
G	2010	Allure	Powertrain	(C) 2.4L LAF Fuel Pump Control Module																																																									
G	2010	Allure	Powertrain	(C) 2.4L LAF Transmission Control Module																																																									
G	2010	Allure	Powertrain	(G) 3.0L LF1 Engine Control Module																																																									
G	2010	Allure	Powertrain	(G) 3.0L LF1 Fuel Pump Control Module																																																									
G	2010	Allure	Powertrain	(G) 3.0L LF1 Transmission Control Module																																																									
G	2010	Allure	Powertrain	(V) 3.6L LLT Engine Control Module																																																									
G	2010	Allure	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																									
G	2010	Allure	Powertrain	(V) 3.6L LLT Transmission Control Module																																																									
G	2010	Allure	Powertrain	Rear Differential Clutch Control Module																																																									
G	2010	Allure	Chassis	Electronic Brake Control Module																																																									
G	2010	Allure	Chassis	Parking Brake Control Module																																																									
G	2010	Allure	Chassis	Multi-Axis Acceleration Sensor Module																																																									
G	2010	Allure	Chassis	Power Steering Control Module	V	V	V																																																						
G	2010	Allure	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
G	2010	Allure	Chassis	Suspension Control Module																																																									
G	2010	Allure	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																																	
G	2010	Allure	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																																	
G	2010	Allure	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																									V	V	V	V	V	V	V																										
G	2010	Allure	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																									V	V	V	V	V	V	V																										
G	2010	Allure	Body	Passenger Presence Module																																V																									
G	2010	Allure	Body	Instrument Cluster																																	V																							
G	2010	Allure	Body	Head-Up Display Module																																																								
G	2010	Allure	Body	Radio																																																								
G	2010	Allure	Body	Digital Radio Receiver Control Module																																																								
G	2010	Allure	Body	Multimedia Player Interface Module																																	V																							
G	2010	Allure	Body	Telematics Communication Interface Control Module Version 8																																		V	V	V	V																		
G	2010	Allure	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
G	2010	Allure	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
G	2010	Allure	Body	Seat Memory Control Module																																																								
G	2010	Allure	Body	Front Seat Heating Control Module																																						V	V																	
G	2010	Allure	Body	Rear Seat Heating Control Module																																								V	V															
G	2010	Allure	Body	Keyless Entry Control Module																																																									
G	2010	Allure	Body	Right Side Object Detection Control Module																																									V	V														
G	2010	Allure	Body	Left Side Object Detection Control Module																																									V	V														
G	2010	Allure	Body	Parking Assist Control Module																																V																									
G	2010	Allure	Body	Steering Column Lock Control Module																																																									
G	2010	Lacrosse	Powertrain	(C) 2.4L LAF Engine Control Module																																																									
G	2010	Lacrosse	Powertrain	(C) 2.4L LAF Fuel Pump Control Module																																																									
G	2010	Lacrosse	Powertrain	(C) 2.4L LAF Transmission Control Module																																																									
G	2010	Lacrosse	Powertrain	(G) 3.0L LF1 Engine Control Module																																																									
G	2010	Lacrosse	Powertrain	(G) 3.0L LF1 Fuel Pump Control Module																																																									
G	2010	Lacrosse	Powertrain	(G) 3.0L LF1 Transmission Control Module																																																									
G	2010	Lacrosse	Powertrain	(V) 3.6L LLT Engine Control Module																																																									
G	2010	Lacrosse	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																									
G	2010	Lacrosse	Powertrain	(V) 3.6L LLT Transmission Control Module																																																									
G	2010	Lacrosse	Powertrain	Rear Differential Clutch Control Module																																																									
G	2010	Lacrosse	Chassis	Electronic Brake Control Module																																																									
G	2010	Lacrosse	Chassis	Parking Brake Control Module																																																									
G	2010	Lacrosse	Chassis	Multi-Axis Acceleration Sensor Module																																																									
G	2010	Lacrosse	Chassis	Power Steering Control Module	V	V	V																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2010	Lacrosse	Chassis	Steering Wheel Angle Sensor Module				V	V																																																						
G	2010	Lacrosse	Chassis	Suspension Control Module																																																												
G	2010	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																																			
G	2010	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																																			
G	2010	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																									V	V	V	V	V	V	V																											
G	2010	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																									V	V	V	V	V	V	V																											
G	2010	Lacrosse	Body	Passenger Presence Module																																V																											
G	2010	Lacrosse	Body	Instrument Cluster																																	V																									
G	2010	Lacrosse	Body	Head-Up Display Module																																																										
G	2010	Lacrosse	Body	Headlamp Control Module																																																										
G	2010	Lacrosse	Body	Radio																																																									
G	2010	Lacrosse	Body	Digital Radio Receiver Control Module																																																									
G	2010	Lacrosse	Body	Multimedia Player Interface Module																																	V																									
G	2010	Lacrosse	Body	Telematics Communication Interface Control Module Version 8																																		V	V	V	V																				
G	2010	Lacrosse	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																				
G	2010	Lacrosse	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
G	2010	Lacrosse	Body	HVAC Control Module Auto Dual (CJ2)																														V												V	V	V	V	V									
G	2010	Lacrosse	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V									
G	2010	Lacrosse	Body	Seat Memory Control Module																																																									
G	2010	Lacrosse	Body	Front Seat Heating Control Module																																					V	V																			
G	2010	Lacrosse	Body	Rear Seat Heating Control Module																																							V	V																
G	2010	Lacrosse	Body	Keyless Entry Control Module																																																									
G	2010	Lacrosse	Body	Right Side Object Detection Control Module																																								V	V															
G	2010	Lacrosse	Body	Left Side Object Detection Control Module																																								V	V															
G	2010	Lacrosse	Body	Parking Assist Control Module																																	V																								
G	2010	Lacrosse	Body	Steering Column Lock Control Module																																																									
G	2011	Lacrosse	Powertrain	(C) 2.4L LAF Engine Control Module																				V																												V								
G	2011	Lacrosse	Powertrain	(C) 2.4L LAF Fuel Pump Control Module																																																									
G	2011	Lacrosse	Powertrain	(C) 2.4L LAF Transmission Control Module																																																									
G	2011	Lacrosse	Powertrain	(Y) 3.0L LF1 Engine Control Module																				V																																					
G	2011	Lacrosse	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																									
G	2011	Lacrosse	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																									
G	2011	Lacrosse	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
G	2011	Lacrosse	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																									
G	2011	Lacrosse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
G	2011	Lacrosse	Powertrain	Rear Differential Clutch Control Module																																																									
G	2011	Lacrosse	Chassis	Electronic Brake Control Module																																																									
G	2011	Lacrosse	Chassis	Parking Brake Control Module																																																									
G	2011	Lacrosse	Chassis	Multi-Axis Acceleration Sensor Module																																																									
G	2011	Lacrosse	Chassis	Power Steering Control Module	V	V	V																																																							
G	2011	Lacrosse	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
G	2011	Lacrosse	Chassis	Suspension Control Module																																																										
G	2011	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V								
G	2011	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V								
G	2011	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																									V	V	V	V	V	V	V																											
G	2011	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																									V	V	V	V	V	V	V																											
G	2011	Lacrosse	Body	Passenger Presence Module																																V																											
G	2011	Lacrosse	Body	Instrument Cluster																																	V																									
G	2011	Lacrosse	Body	Head-Up Display Module																																																										
G	2011	Lacrosse	Body	Headlamp Control Module																																																										
G	2011	Lacrosse	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2011	Lacrosse	Body	Digital Radio Receiver Control Module																																																									
G	2011	Lacrosse	Body	Multimedia Player Interface Module																																V																									
G	2011	Lacrosse	Body	Telematics Communication Interface Control Module Version 8																																	V	V	V	V																				
G	2011	Lacrosse	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
G	2011	Lacrosse	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
G	2011	Lacrosse	Body	HVAC Control Module Auto Dual (CJ2)																														V												V	V	V	V	V								
G	2011	Lacrosse	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V								
G	2011	Lacrosse	Body	Seat Memory Control Module																																																								
G	2011	Lacrosse	Body	Front Seat Heating Control Module																																						V	V																	
G	2011	Lacrosse	Body	Rear Seat Heating Control Module																																								V	V															
G	2011	Lacrosse	Body	Keyless Entry Control Module																																																								
G	2011	Lacrosse	Body	Right Side Object Detection Control Module																																										V	V													
G	2011	Lacrosse	Body	Left Side Object Detection Control Module																																										V	V													
G	2011	Lacrosse	Body	Parking Assist Control Module																																V																									
G	2011	Lacrosse	Body	Steering Column Lock Control Module																																																								
G	2011	Regal	Powertrain	(V) 2.0L LHU Engine Control Module																				V																																					
G	2011	Regal	Powertrain	(V) 2.0L LHU Transmission Control Module																																																			V	V				
G	2011	Regal	Powertrain	(C) 2.4L LAF Engine Control Module																				V																													V						
G	2011	Regal	Powertrain	(C) 2.4L LAF Transmission Control Module																																																								
G	2011	Regal	Powertrain	Fuel Pump Control Module																																																								
G	2011	Regal	Powertrain	Rear Differential Clutch Control Module																																																								
G	2011	Regal	Chassis	Electronic Brake Control Module																																																								
G	2011	Regal	Chassis	Parking Brake Control Module																																																								
G	2011	Regal	Chassis	Multi-Axis Acceleration Sensor Module																																																								
G	2011	Regal	Chassis	Power Steering Control Module	V	V	V																																																					
G	2011	Regal	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
G	2011	Regal	Chassis	Suspension Control Module																																																								
G	2011	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																									V							
G	2011	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																									V							
G	2011	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																									V	V	V	V	V	V	V																								
G	2011	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																									V	V	V	V	V	V	V																								
G	2011	Regal	Body	Passenger Presence Module																															V																									
G	2011	Regal	Body	Instrument Cluster																																V																								
G	2011	Regal	Body	Head-Up Display Module																																																								
G	2011	Regal	Body	Radio																																																								
G	2011	Regal	Body	Digital Radio Receiver Control Module																																																								
G	2011	Regal	Body	Multimedia Player Interface Module																																V																								
G	2011	Regal	Body	Telematics Communication Interface Control Module Version 8																																	V	V	V	V																				
G	2011	Regal	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
G	2011	Regal	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
G	2011	Regal	Body	Remote Heater and Air Conditioning Control Module																														V												V	V	V	V	V								
G	2011	Regal	Body	Seat Memory Control Module																																																								
G	2011	Regal	Body	Front Seat Heating Control Module																																						V	V																	
G	2011	Regal	Body	Rear Seat Heating Control Module																																								V	V															
G	2011	Regal	Body	Keyless Entry Control Module																																																								
G	2011	Regal	Body	Right Side Object Detection Control Module																																										V	V													
G	2011	Regal	Body	Left Side Object Detection Control Module																																										V	V													
G	2011	Regal	Body	Parking Assist Control Module																																V																									
G	2011	Regal	Body	Steering Column Lock Control Module																																																								
G	2012	Lacrosse	Powertrain	(M) 2.4L LAF Engine Control Module																				V																																					
G	2012	Lacrosse	Powertrain	(M) 2.4L LAF Fuel Pump Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2012	Lacrosse	Powertrain	(M) 2.4L LAF Transmission Control Module																																																								
G	2012	Lacrosse	Powertrain	(R) 2.4L LUK Engine Control Module																																																								
G	2012	Lacrosse	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																								
G	2012	Lacrosse	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																				V	V		
G	2012	Lacrosse	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																				V																																		V	V
G	2012	Lacrosse	Powertrain	(R) 2.4L LUK Transmission Control Module																																																							
G	2012	Lacrosse	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																			
G	2012	Lacrosse	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																							
G	2012	Lacrosse	Powertrain	(5) 3.0L LFW Transmission Control Module																																																							
G	2012	Lacrosse	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																			
G	2012	Lacrosse	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																							
G	2012	Lacrosse	Powertrain	(3) 3.6L LFX Transmission Control Module																																																							
G	2012	Lacrosse	Powertrain	Rear Differential Clutch Control Module																																																							
G	2012	Lacrosse	Chassis	Electronic Brake Control Module																																																							
G	2012	Lacrosse	Chassis	Parking Brake Control Module																																																							
G	2012	Lacrosse	Chassis	Multi-Axis Acceleration Sensor Module																																																							
G	2012	Lacrosse	Chassis	Power Steering Control Module	V	V	V																																																					
G	2012	Lacrosse	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
G	2012	Lacrosse	Chassis	Suspension Control Module																																																							
G	2012	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V							
G	2012	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V							
G	2012	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																									V	V	V	V	V	V	V																							
G	2012	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																									V	V	V	V	V	V	V																							
G	2012	Lacrosse	Body	Passenger Presence Module																																V																							
G	2012	Lacrosse	Body	Instrument Cluster																																	V																						
G	2012	Lacrosse	Body	Head-Up Display Module																																																							
G	2012	Lacrosse	Body	Headlamp Control Module																																																							
G	2012	Lacrosse	Body	Radio																																																							
G	2012	Lacrosse	Body	Digital Radio Receiver Control Module																																																							
G	2012	Lacrosse	Body	Multimedia Player Interface Module																																	V																						
G	2012	Lacrosse	Body	Telematics Communication Interface Control Module Version 8																																		V	V	V	V																	
G	2012	Lacrosse	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																	
G	2012	Lacrosse	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
G	2012	Lacrosse	Body	HVAC Control Module Auto Dual (CJ2)																														V											V	V	V	V	V								
G	2012	Lacrosse	Body	HVAC Control Module Auto Single (C68)																														V											V	V	V	V	V								
G	2012	Lacrosse	Body	Seat Memory Control Module																																																							
G	2012	Lacrosse	Body	Front Seat Heating Control Module																																						V	V																	
G	2012	Lacrosse	Body	Rear Seat Heating Control Module																																								V	V															
G	2012	Lacrosse	Body	Keyless Entry Control Module																																																							
G	2012	Lacrosse	Body	Right Side Object Detection Control Module																																									V	V													
G	2012	Lacrosse	Body	Left Side Object Detection Control Module																																									V	V													
G	2012	Lacrosse	Body	Parking Assist Control Module																																	V																						
G	2012	Lacrosse	Body	Steering Column Lock Control Module																																																							
G	2012	Lacrosse	Body	Battery Energy Control Module																																																							
G	2012	Regal	Powertrain	(V) 2.0L LHU Engine Control Module																				V																																			
G	2012	Regal	Powertrain	(V) 2.0L LHU Transmission Control Module T76 (MHK)																																																							
G	2012	Regal	Powertrain	(V) 2.0L LHU Transmission Control Module AF40 Gen II (MDK)																																																	V	V				
G	2012	Regal	Powertrain	2.0L LTD Engine Control Module																				V																																			
G	2012	Regal	Powertrain	2.0L LTD Transmission Control Module																																																							
G	2012	Regal	Powertrain	(K) 2.4L LEA Engine Control Module																				V																												V						
G	2012	Regal	Powertrain	(K) 2.4L LEA Transmission Control Module																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2012	Regal	Powertrain	(R) 2.4L LUK Engine Control Module																																																								
G	2012	Regal	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																									
G	2012	Regal	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																				V																																			V	V
G	2012	Regal	Powertrain	(R) 2.4L LUK Transmission Control Module																																																								
G	2012	Regal	Powertrain	Fuel Pump Control Module																																																								
G	2012	Regal	Powertrain	Rear Differential Clutch Control Module																																																								
G	2012	Regal	Chassis	Electronic Brake Control Module																																																								
G	2012	Regal	Chassis	Parking Brake Control Module																																																								
G	2012	Regal	Chassis	Multi-Axis Acceleration Sensor Module																																																								
G	2012	Regal	Chassis	Power Steering Control Module	V	V	V																																																						
G	2012	Regal	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
G	2012	Regal	Chassis	Suspension Control Module																																																								
G	2012	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V								
G	2012	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V								
G	2012	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																									V	V	V	V	V	V	V																								
G	2012	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																									V	V	V	V	V	V	V																								
G	2012	Regal	Body	Passenger Presence Module																																V																								
G	2012	Regal	Body	Instrument Cluster																																	V																						
G	2012	Regal	Body	Head-Up Display Module																																																								
G	2012	Regal	Body	Radio																																																								
G	2012	Regal	Body	Digital Radio Receiver Control Module																																																								
G	2012	Regal	Body	Multimedia Player Interface Module																																	V																						
G	2012	Regal	Body	Telematics Communication Interface Control Module Version 8																																		V	V	V	V																		
G	2012	Regal	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
G	2012	Regal	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
G	2012	Regal	Body	Remote Heater and Air Conditioning Control Module																														V												V	V	V	V	V								
G	2012	Regal	Body	Seat Memory Control Module																																																								
G	2012	Regal	Body	Front Seat Heating Control Module																																						V	V																	
G	2012	Regal	Body	Rear Seat Heating Control Module																																								V	V															
G	2012	Regal	Body	Keyless Entry Control Module																																																								
G	2012	Regal	Body	Right Side Object Detection Control Module																																										V	V													
G	2012	Regal	Body	Left Side Object Detection Control Module																																										V	V													
G	2012	Regal	Body	Parking Assist Control Module																																	V																						
G	2012	Regal	Body	Steering Column Lock Control Module																																																							
G	2012	Regal	Body	Battery Energy Control Module																																																							
G	2013	Lacrosse	Powertrain	(R) 2.4L LUK Engine Control Module																																																								
G	2013	Lacrosse	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																								
G	2013	Lacrosse	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																			V	V		
G	2013	Lacrosse	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																				V																																			V	V
G	2013	Lacrosse	Powertrain	(R) 2.4L LUK Transmission Control Module																																																								
G	2013	Lacrosse	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
G	2013	Lacrosse	Powertrain	(3) 3.6L LFX Fuel Injector Control Module																																																								
G	2013	Lacrosse	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
G	2013	Lacrosse	Powertrain	Rear Differential Clutch Control Module																																																								
G	2013	Lacrosse	Chassis	Electronic Brake Control Module																																																								
G	2013	Lacrosse	Chassis	Parking Brake Control Module																																																								
G	2013	Lacrosse	Chassis	Multi-Axis Acceleration Sensor Module																																																								
G	2013	Lacrosse	Chassis	Power Steering Control Module	V	V																																																						
G	2013	Lacrosse	Chassis	Power Steering Control Module			V																																																					
G	2013	Lacrosse	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
G	2013	Lacrosse	Chassis	Suspension Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2013	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V	V			V	V	V	V	V	V	V	V																							V							
G	2013	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V	V			V	V	V	V	V	V	V	V																							V							
G	2013	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
G	2013	Lacrosse	Body	Passenger Presence Module																															V																								
G	2013	Lacrosse	Body	Instrument Cluster																																V																							
G	2013	Lacrosse	Body	Head-Up Display Module																																																						
G	2013	Lacrosse	Body	Headlamp Control Module																																																						
G	2013	Lacrosse	Body	Radio																																																						
G	2013	Lacrosse	Body	Rear Audio Control Module																																																						
G	2013	Lacrosse	Body	Multimedia Player Interface Module																																V																							
G	2013	Lacrosse	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																		
G	2013	Lacrosse	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
G	2013	Lacrosse	Body	HVAC Control Module																														V												V	V	V	V	V								
G	2013	Lacrosse	Body	Seat Memory Control Module																																																						
G	2013	Lacrosse	Body	Front Seat Heating Control Module																																					V	V																		
G	2013	Lacrosse	Body	Keyless Entry Control Module																																																						
G	2013	Lacrosse	Body	Right Side Object Detection Control Module																																								V	V														
G	2013	Lacrosse	Body	Left Side Object Detection Control Module																																								V	V														
G	2013	Lacrosse	Body	Parking Assist Control Module																																V																							
G	2013	Lacrosse	Body	Steering Column Lock Control Module																																																						
G	2013	Lacrosse	Body	Battery Energy Control Module																																																						
G	2013	Regal	Powertrain	(V) 2.0L LHU Engine Control Module																				V																																			
G	2013	Regal	Powertrain	(V) 2.0L LHU Transmission Control Module T76 (MHK)																																																						
G	2013	Regal	Powertrain	(V) 2.0L LHU Transmission Control Module AF40 Gen II (MDK)																																																	V	V				
G	2013	Regal	Powertrain	(R) 2.4L LUK Engine Control Module																																																						
G	2013	Regal	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																						
G	2013	Regal	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																						
G	2013	Regal	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																				V																																		V	V
G	2013	Regal	Powertrain	(R) 2.4L LUK Transmission Control Module																																																						
G	2013	Regal	Powertrain	Fuel Injector Control Module																																																						
G	2013	Regal	Powertrain	Rear Differential Clutch Control Module																																																						
G	2013	Regal	Chassis	Electronic Brake Control Module																																																						
G	2013	Regal	Chassis	Parking Brake Control Module																																																						
G	2013	Regal	Chassis	Multi-Axis Acceleration Sensor Module																																																						
G	2013	Regal	Chassis	Power Steering Control Module	V	V																																																				
G	2013	Regal	Chassis	Power Steering Control Module			V																																																			
G	2013	Regal	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
G	2013	Regal	Chassis	Suspension Control Module																																																						
G	2013	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V	V			V	V	V	V	V	V	V	V																							V							
G	2013	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V	V			V	V	V	V	V	V	V	V																							V							
G	2013	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
G	2013	Regal	Body	Passenger Presence Module																																V																							
G	2013	Regal	Body	Instrument Cluster																																V																							
G	2013	Regal	Body	Radio																																																						
G	2013	Regal	Body	Multimedia Player Interface Module																																V																							
G	2013	Regal	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																		
G	2013	Regal	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
G	2013	Regal	Body	HVAC Control Module																														V												V	V	V	V	V								
G	2013	Regal	Body	Front Seat Heating Control Module																																					V	V																
G	2013	Regal	Body	Keyless Entry Control Module																																																						
G	2013	Regal	Body	Parking Assist Control Module																																V																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2013	Regal	Body	Steering Column Lock Control Module																																																								
G	2013	Regal	Body	Battery Energy Control Module																																																								
G	2014	Lacrosse	Powertrain	(R) 2.4L LUK Engine Control Module																																																								
G	2014	Lacrosse	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																								
G	2014	Lacrosse	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																				V																																			V	V
G	2014	Lacrosse	Powertrain	(R) 2.4L LUK Transmission Control Module																																																								
G	2014	Lacrosse	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
G	2014	Lacrosse	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
G	2014	Lacrosse	Powertrain	Chassis Control Module																																																			V	V			
G	2014	Lacrosse	Powertrain	Rear Differential Clutch Control Module																																																								
G	2014	Lacrosse	Chassis	Electronic Brake Control Module					V																																																			
G	2014	Lacrosse	Chassis	Distance Sensing Cruise Control Module																																																								
G	2014	Lacrosse	Chassis	Parking Brake Control Module																																																								
G	2014	Lacrosse	Chassis	Multi-Axis Acceleration Sensor Module																																																								
G	2014	Lacrosse	Chassis	Power Steering Control Module	V	V																																																						
G	2014	Lacrosse	Chassis	Power Steering Control Module			V																																																					
G	2014	Lacrosse	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
G	2014	Lacrosse	Chassis	Suspension Control Module																																																								
G	2014	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V							
G	2014	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V							
G	2014	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
G	2014	Lacrosse	Body	Passenger Presence Module																																V																							
G	2014	Lacrosse	Body	Instrument Cluster																																	V																					
G	2014	Lacrosse	Body	Head-Up Display Module																																																							
G	2014	Lacrosse	Body	Radio Controls																																																							
G	2014	Lacrosse	Body	HVAC Controls																																																							
G	2014	Lacrosse	Body	Headlamp Control Module																																																							
G	2014	Lacrosse	Body	Radio																																																							
G	2014	Lacrosse	Body	Amplifier																																																							
G	2014	Lacrosse	Body	Media Disc Player																																																							
G	2014	Lacrosse	Body	Human Machine Interface Control Module																																																							
G	2014	Lacrosse	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																			
G	2014	Lacrosse	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
G	2014	Lacrosse	Body	HVAC Control Module																														V												V	V	V	V	V								
G	2014	Lacrosse	Body	Seat Memory Control Module - Driver																																																							
G	2014	Lacrosse	Body	Keyless Entry Control Module																																																							
G	2014	Lacrosse	Body	Left Side Object Detection Control Module																																																							
G	2014	Lacrosse	Body	Parking Assist Control Module																																V																							
G	2014	Lacrosse	Body	Frontview Camera Module																																																							
G	2014	Lacrosse	Body	Battery Energy Control Module																																																							
G	2014	Regal	Powertrain	(X) 2.0L LTG Engine Control Module																				V																																				
G	2014	Regal	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
G	2014	Regal	Powertrain	(K) 2.4L LEA Engine Control Module																				V																																				
G	2014	Regal	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
G	2014	Regal	Powertrain	(R) 2.4L LUK Engine Control Module																																																								
G	2014	Regal	Powertrain	(R) 2.4L LUK Chassis Control Module																																																								
G	2014	Regal	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																								
G	2014	Regal	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																				V																																			V	V
G	2014	Regal	Powertrain	(R) 2.4L LUK Transmission Control Module																																																								
G	2014	Regal	Powertrain	Rear Differential Clutch Control Module																																																								
G	2014	Regal	Chassis	Electronic Brake Control Module					V																																																			

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2014	Regal	Chassis	Distance Sensing Cruise Control Module																																																								
G	2014	Regal	Chassis	Parking Brake Control Module																																																								
G	2014	Regal	Chassis	Multi-Axis Acceleration Sensor Module																																																								
G	2014	Regal	Chassis	Power Steering Control Module TRW Belt Drive - Global A EPS			V																																																					
G	2014	Regal	Chassis	Power Steering Control Module PSCM - Global A - EPS	V	V	V																																																					
G	2014	Regal	Chassis	Power Steering Control Module PSCM - Global A - VES																																																								
G	2014	Regal	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
G	2014	Regal	Chassis	Suspension Control Module																																																								
G	2014	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																										V						
G	2014	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																										V						
G	2014	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																									
G	2014	Regal	Body	Passenger Presence Module																															V																									
G	2014	Regal	Body	Instrument Cluster																																V																								
G	2014	Regal	Body	Radio Controls																																																								
G	2014	Regal	Body	HVAC Controls																																																								
G	2014	Regal	Body	Radio																																																								
G	2014	Regal	Body	Amplifier																																																								
G	2014	Regal	Body	Human Machine Interface Control Module																																																								
G	2014	Regal	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
G	2014	Regal	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
G	2014	Regal	Body	HVAC Control Module																														V													V	V	V	V	V									
G	2014	Regal	Body	Seat Memory Control Module - Driver																																																								
G	2014	Regal	Body	Front Seat Heating Control Module																																				V	V																			
G	2014	Regal	Body	Keyless Entry Control Module																																																								
G	2014	Regal	Body	Left Side Object Detection Control Module																																																								
G	2014	Regal	Body	Parking Assist Control Module																																V																								
G	2014	Regal	Body	Frontview Camera Module																																																								
G	2014	Regal	Body	Battery Energy Control Module																																																								
G	2015	Lacrosse	Powertrain	(R) 2.4L LUK Engine Control Module																																																								
G	2015	Lacrosse	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																								
G	2015	Lacrosse	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																				V																																			V	V
G	2015	Lacrosse	Powertrain	(R) 2.4L LUK Transmission Control Module																																																								
G	2015	Lacrosse	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
G	2015	Lacrosse	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
G	2015	Lacrosse	Powertrain	Chassis Control Module																																																		V	V					
G	2015	Lacrosse	Powertrain	Rear Differential Clutch Control Module																																																								
G	2015	Lacrosse	Chassis	Electronic Brake Control Module					V																																																			
G	2015	Lacrosse	Chassis	Distance Sensing Cruise Control Module																																																								
G	2015	Lacrosse	Chassis	Parking Brake Control Module																																																								
G	2015	Lacrosse	Chassis	Power Steering Control Module	V	V																																																						
G	2015	Lacrosse	Chassis	Power Steering Control Module			V																																																					
G	2015	Lacrosse	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
G	2015	Lacrosse	Chassis	Suspension Control Module																																																								
G	2015	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																										V						
G	2015	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																										V						
G	2015	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																									
G	2015	Lacrosse	Body	Passenger Presence Module																															V																									
G	2015	Lacrosse	Body	Instrument Cluster																																V																								
G	2015	Lacrosse	Body	Head-Up Display Module																																																								
G	2015	Lacrosse	Body	Radio Controls																																																								
G	2015	Lacrosse	Body	HVAC Controls																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2015	Lacrosse	Body	Headlamp Control Module																																																								
G	2015	Lacrosse	Body	Radio																																																								
G	2015	Lacrosse	Body	Amplifier																																																								
G	2015	Lacrosse	Body	Media Disc Player																																																								
G	2015	Lacrosse	Body	Human Machine Interface Control Module																																																								
G	2015	Lacrosse	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
G	2015	Lacrosse	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
G	2015	Lacrosse	Body	HVAC Control Module																														V													V	V	V	V	V									
G	2015	Lacrosse	Body	Seat Memory Control Module - Driver																																																								
G	2015	Lacrosse	Body	Keyless Entry Control Module																																																								
G	2015	Lacrosse	Body	Left Side Object Detection Control Module																																																								
G	2015	Lacrosse	Body	Parking Assist Control Module																																V																								
G	2015	Lacrosse	Body	Frontview Camera Module																																																								
G	2015	Lacrosse	Body	Battery Energy Control Module																																																								
G	2015	Regal	Powertrain	(X) 2.0L LTG Engine Control Module																				V																																				
G	2015	Regal	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
G	2015	Regal	Powertrain	(K) 2.4L LEA Engine Control Module																				V																																				
G	2015	Regal	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
G	2015	Regal	Powertrain	(R) 2.4L LUK Engine Control Module																																																								
G	2015	Regal	Powertrain	(R) 2.4L LUK Chassis Control Module																																																								
G	2015	Regal	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																								
G	2015	Regal	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																				V																																			V	V
G	2015	Regal	Powertrain	(R) 2.4L LUK Transmission Control Module																																																								
G	2015	Regal	Powertrain	Rear Differential Clutch Control Module																																																								
G	2015	Regal	Chassis	Electronic Brake Control Module				V																																																				
G	2015	Regal	Chassis	Distance Sensing Cruise Control Module																																																								
G	2015	Regal	Chassis	Parking Brake Control Module																																																								
G	2015	Regal	Chassis	Power Steering Control Module	V	V	V																																																					
G	2015	Regal	Chassis	Power Steering Control Module			V																																																					
G	2015	Regal	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
G	2015	Regal	Chassis	Suspension Control Module																																																								
G	2015	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																									V							
G	2015	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																									V							
G	2015	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
G	2015	Regal	Body	Passenger Presence Module																					V																																			
G	2015	Regal	Body	Instrument Cluster																																	V																							
G	2015	Regal	Body	Radio Controls																																																								
G	2015	Regal	Body	HVAC Controls																																																								
G	2015	Regal	Body	Radio																																																								
G	2015	Regal	Body	Amplifier																																																								
G	2015	Regal	Body	Human Machine Interface Control Module																																																								
G	2015	Regal	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
G	2015	Regal	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
G	2015	Regal	Body	HVAC Control Module																														V													V	V	V	V	V									
G	2015	Regal	Body	Seat Memory Control Module - Driver																																																								
G	2015	Regal	Body	Front Seat Heating Control Module																																					V	V																		
G	2015	Regal	Body	Keyless Entry Control Module																																																								
G	2015	Regal	Body	Left Side Object Detection Control Module																																																								
G	2015	Regal	Body	Parking Assist Control Module																																V																								
G	2015	Regal	Body	Frontview Camera Module																																																								
G	2015	Regal	Body	Battery Energy Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2016	Lacrosse	Powertrain	(R) 2.4L LUK Engine Control Module																																																								
G	2016	Lacrosse	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																									
G	2016	Lacrosse	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																				V																																			V	V
G	2016	Lacrosse	Powertrain	(R) 2.4L LUK Transmission Control Module																																																								
G	2016	Lacrosse	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
G	2016	Lacrosse	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
G	2016	Lacrosse	Chassis	Electronic Brake Control Module					V																																																			
G	2016	Lacrosse	Chassis	Distance Sensing Cruise Control Module																																																								
G	2016	Lacrosse	Chassis	Parking Brake Control Module																																																								
G	2016	Lacrosse	Chassis	Power Steering Control Module	V	V																																																						
G	2016	Lacrosse	Chassis	Power Steering Control Module			V																																																					
G	2016	Lacrosse	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
G	2016	Lacrosse	Chassis	Suspension Control Module																																																								
G	2016	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V							
G	2016	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V							
G	2016	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
G	2016	Lacrosse	Body	Passenger Presence Module																																V																							
G	2016	Lacrosse	Body	Instrument Cluster																																	V																						
G	2016	Lacrosse	Body	Head-Up Display Module																																																							
G	2016	Lacrosse	Body	Radio Controls																																																							
G	2016	Lacrosse	Body	HVAC Controls																																																							
G	2016	Lacrosse	Body	Headlamp Control Module																																																							
G	2016	Lacrosse	Body	Radio																																																							
G	2016	Lacrosse	Body	Amplifier																																																							
G	2016	Lacrosse	Body	Rear Audio Control Module																																																							
G	2016	Lacrosse	Body	Media Disc Player																																																							
G	2016	Lacrosse	Body	Infotainment Control Touchpad																																																							
G	2016	Lacrosse	Body	Human Machine Interface Control Module																																																							
G	2016	Lacrosse	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
G	2016	Lacrosse	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
G	2016	Lacrosse	Body	HVAC Control Module																														V													V	V	V	V	V								
G	2016	Lacrosse	Body	Seat Memory Control Module - Driver																																																							
G	2016	Lacrosse	Body	Keyless Entry Control Module																																																							
G	2016	Lacrosse	Body	Left Side Object Detection Control Module																																																							
G	2016	Lacrosse	Body	Parking Assist Control Module																																	V																						
G	2016	Lacrosse	Body	Frontview Camera Module																																																							
G	2016	Lacrosse	Body	Battery Energy Control Module																																																							
G	2016	Regal	Powertrain	(X) 2.0L LTG Engine Control Module																				V																																				
G	2016	Regal	Powertrain	(X) 2.0L LTG Transmission Control Module																																																							
G	2016	Regal	Powertrain	(K) 2.4L LEA Engine Control Module																				V																																				
G	2016	Regal	Powertrain	(K) 2.4L LEA Transmission Control Module																																																							
G	2016	Regal	Powertrain	(R) 2.4L LUK Engine Control Module																																																							
G	2016	Regal	Powertrain	(R) 2.4L LUK Chassis Control Module																																																							
G	2016	Regal	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																							
G	2016	Regal	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																				V																																			V	V
G	2016	Regal	Powertrain	(R) 2.4L LUK Transmission Control Module																																																							
G	2016	Regal	Powertrain	Rear Differential Clutch Control Module																																																							
G	2016	Regal	Chassis	Electronic Brake Control Module					V																																																		
G	2016	Regal	Chassis	Distance Sensing Cruise Control Module																																																							
G	2016	Regal	Chassis	Parking Brake Control Module																																																							
G	2016	Regal	Chassis	Power Steering Control Module	V	V	V																																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2016	Regal	Chassis	Power Steering Control Module			V																																																						
G	2016	Regal	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
G	2016	Regal	Chassis	Suspension Control Module																																																									
G	2016	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V							
G	2016	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V							
G	2016	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
G	2016	Regal	Body	Passenger Presence Module																																V																									
G	2016	Regal	Body	Instrument Cluster																																	V																							
G	2016	Regal	Body	Radio Controls																																																							
G	2016	Regal	Body	HVAC Controls																																																							
G	2016	Regal	Body	Radio																																																							
G	2016	Regal	Body	Amplifier																																																							
G	2016	Regal	Body	Infotainment Control Touchpad																																																							
G	2016	Regal	Body	Human Machine Interface Control Module																																																							
G	2016	Regal	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
G	2016	Regal	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
G	2016	Regal	Body	HVAC Control Module																														V													V	V	V	V	V								
G	2016	Regal	Body	Seat Memory Control Module - Driver																																																							
G	2016	Regal	Body	Front Seat Heating Control Module																																					V	V																		
G	2016	Regal	Body	Keyless Entry Control Module																																																							
G	2016	Regal	Body	Left Side Object Detection Control Module																																																							
G	2016	Regal	Body	Parking Assist Control Module																																	V																							
G	2016	Regal	Body	Frontview Camera Module																																																							
G	2016	Regal	Body	Battery Energy Control Module																																																							
P	2012	Verano	Powertrain	(K) 2.4L LEA Engine Control Module																				V																																				
P	2012	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
P	2012	Verano	Powertrain	Fuel Pump Control Module																																																								
P	2012	Verano	Chassis	Electronic Brake Control Module																																																								
P	2012	Verano	Chassis	Parking Brake Control Module																																																								
P	2012	Verano	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2012	Verano	Chassis	Power Steering Control Module	V	V	V																																																					
P	2012	Verano	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
P	2012	Verano	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V		V	V	V	V	V		V	V																								V							
P	2012	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
P	2012	Verano	Body	Passenger Presence Module																																V																									
P	2012	Verano	Body	Instrument Cluster																																	V																							
P	2012	Verano	Body	Headlamp Control Module																																																								
P	2012	Verano	Body	Radio																																																								
P	2012	Verano	Body	Telematics Communication Interface Control Module Version 8																																	V	V	V	V																				
P	2012	Verano	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
P	2012	Verano	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
P	2012	Verano	Body	HVAC Control Module Auto Dual (CJ2)																														V													V	V	V	V	V								
P	2012	Verano	Body	HVAC Control Module Manual Single (C67)																														V													V	V	V	V	V								
P	2012	Verano	Body	Front Seat Heating Control Module																																					V	V																		
P	2012	Verano	Body	Keyless Entry Control Module																																																								
P	2012	Verano	Body	Parking Assist Control Module																																	V																							
P	2013	Verano	Powertrain	(V) 2.0L LHU Engine Control Module Automatic Transmission																				V																																				
P	2013	Verano	Powertrain	(V) 2.0L LHU Engine Control Module Manual Transmission																				V																																				
P	2013	Verano	Powertrain	(V) 2.0L LHU Transmission Control Module																																																							
P	2013	Verano	Powertrain	(K) 2.4L LEA Engine Control Module																				V																																				
P	2013	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2013	Verano	Powertrain	Fuel Pump Control Module																																																										
P	2013	Verano	Chassis	Electronic Brake Control Module					V																																																					
P	2013	Verano	Chassis	Parking Brake Control Module																																																										
P	2013	Verano	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2013	Verano	Chassis	Power Steering Control Module	V	V																																																								
P	2013	Verano	Chassis	Power Steering Control Module			V																																																							
P	2013	Verano	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
P	2013	Verano	Body	Body Control Module						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																														V					
P	2013	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																												
P	2013	Verano	Body	Passenger Presence Module																															V																											
P	2013	Verano	Body	Instrument Cluster																																V																										
P	2013	Verano	Body	Radio																																																										
P	2013	Verano	Body	Multimedia Player Interface Module																																V																										
P	2013	Verano	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																						
P	2013	Verano	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																							
P	2013	Verano	Body	HVAC Control Module Auto Dual (CJ2)																														V													V	V		V											
P	2013	Verano	Body	HVAC Control Module Manual Single (C67)																														V													V	V		V											
P	2013	Verano	Body	Front Seat Heating Control Module																																				V	V																					
P	2013	Verano	Body	Keyless Entry Control Module																																																										
P	2013	Verano	Body	Right Side Object Detection Control Module																																																										
P	2013	Verano	Body	Left Side Object Detection Control Module																																																										
P	2013	Verano	Body	Parking Assist Control Module																																V																										
P	2014	Verano	Powertrain	(V) 2.0L LHU Engine Control Module Automatic Transmission																				V																																						
P	2014	Verano	Powertrain	(V) 2.0L LHU Engine Control Module Manual Transmission																				V																																						
P	2014	Verano	Powertrain	(V) 2.0L LHU Transmission Control Module																																																										
P	2014	Verano	Powertrain	(K) 2.4L LEA Engine Control Module																				V																																						
P	2014	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
P	2014	Verano	Powertrain	Fuel Pump Control Module																																																										
P	2014	Verano	Chassis	Electronic Brake Control Module																																																										
P	2014	Verano	Chassis	Parking Brake Control Module																																																										
P	2014	Verano	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2014	Verano	Chassis	Power Steering Control Module	V	V	V																																																							
P	2014	Verano	Chassis	Power Steering Control Module			V																																																							
P	2014	Verano	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
P	2014	Verano	Body	Body Control Module						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																														V					
P	2014	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																												
P	2014	Verano	Body	Passenger Presence Module																															V																											
P	2014	Verano	Body	Instrument Cluster																																V																										
P	2014	Verano	Body	Radio																																																										
P	2014	Verano	Body	Multimedia Player Interface Module																																V																										
P	2014	Verano	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																						
P	2014	Verano	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																							
P	2014	Verano	Body	HVAC Control Module Auto Dual (CJ2)																														V													V	V		V											
P	2014	Verano	Body	HVAC Control Module Manual Single (C67)																														V													V	V		V											
P	2014	Verano	Body	Front Seat Heating Control Module																																				V	V																					
P	2014	Verano	Body	Keyless Entry Control Module																																																										
P	2014	Verano	Body	Left Side Object Detection Control Module																																																										
P	2014	Verano	Body	Parking Assist Control Module																																V																										
P	2014	Verano	Body	Frontview Camera Module																																																										
P	2015	Verano	Powertrain	(V) 2.0L LHU Engine Control Module																				V																																						
P	2015	Verano	Powertrain	(V) 2.0L LHU Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2015	Verano	Powertrain	(K) 2.4L LEA Engine Control Module																				V																																						
P	2015	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
P	2015	Verano	Powertrain	Chassis Control Module																																																										
P	2015	Verano	Chassis	Electronic Brake Control Module					V																																																					
P	2015	Verano	Chassis	Parking Brake Control Module																																																										
P	2015	Verano	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2015	Verano	Chassis	Power Steering Control Module	V	V	V																																																							
P	2015	Verano	Chassis	Power Steering Control Module			V																																																							
P	2015	Verano	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
P	2015	Verano	Body	Body Control Module						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V									
P	2015	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
P	2015	Verano	Body	Passenger Presence Module																																V																											
P	2015	Verano	Body	Instrument Cluster																																	V																									
P	2015	Verano	Body	Radio																																																									
P	2015	Verano	Body	Multimedia Player Interface Module																																	V																									
P	2015	Verano	Body	Telematics Communication Interface Control Module Version 9.7																																		V	V	V																					
P	2015	Verano	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																					
P	2015	Verano	Body	HVAC Control Module Auto Dual (CJ2)																														V													V	V		V									
P	2015	Verano	Body	HVAC Control Module Manual Single (C67)																														V													V	V		V									
P	2015	Verano	Body	Front Seat Heating Control Module																																					V	V																			
P	2015	Verano	Body	Keyless Entry Control Module																																																									
P	2015	Verano	Body	Right Side Object Detection Control Module																																																									
P	2015	Verano	Body	Left Side Object Detection Control Module																																																									
P	2015	Verano	Body	Parking Assist Control Module																																	V																									
P	2015	Verano	Body	Frontview Camera Module																																																									
P	2016	Verano	Powertrain	2.0L LHU Engine Control Module Automatic Transmission																				V																																					
P	2016	Verano	Powertrain	2.0L LHU Engine Control Module Manual Transmission																				V																																					
P	2016	Verano	Powertrain	2.0L LHU Transmission Control Module																																																									
P	2016	Verano	Powertrain	(K) 2.4L LEA Engine Control Module																				V																																					
P	2016	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
P	2016	Verano	Powertrain	Chassis Control Module																																																									
P	2016	Verano	Chassis	Electronic Brake Control Module					V																																																				
P	2016	Verano	Chassis	Parking Brake Control Module																																																									
P	2016	Verano	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2016	Verano	Chassis	Power Steering Control Module	V	V																																																							
P	2016	Verano	Chassis	Power Steering Control Module			V																																																						
P	2016	Verano	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
P	2016	Verano	Body	Body Control Module						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V									
P	2016	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
P	2016	Verano	Body	Passenger Presence Module																																V																											
P	2016	Verano	Body	Instrument Cluster																																	V																									
P	2016	Verano	Body	Radio																																																									
P	2016	Verano	Body	Multimedia Player Interface Module																																	V																									
P	2016	Verano	Body	Telematics Communication Interface Control Module Version 9.7																																		V	V	V																					
P	2016	Verano	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																					
P	2016	Verano	Body	HVAC Control Module Auto Dual (CJ2)																														V													V	V		V									
P	2016	Verano	Body	HVAC Control Module Manual Single (C67)																														V													V	V		V									
P	2016	Verano	Body	Front Seat Heating Control Module																																					V	V																			
P	2016	Verano	Body	Keyless Entry Control Module																																																									
P	2016	Verano	Body	Right Side Object Detection Control Module																																																									
P	2016	Verano	Body	Left Side Object Detection Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2016	Verano	Body	Parking Assist Control Module																																	V																									
P	2016	Verano	Body	Frontview Camera Module																																																										
W	2016	Cascada	Powertrain	(5) 1.6L LWC Engine Control Module																				V																																						
W	2016	Cascada	Powertrain	(5) 1.6L LWC Transmission Control Module																																																										
W	2016	Cascada	Chassis	Electronic Brake Control Module					V																																																					
W	2016	Cascada	Chassis	Parking Brake Control Module																																																										
W	2016	Cascada	Chassis	Multi-Axis Acceleration Sensor Module																																																										
W	2016	Cascada	Chassis	Power Steering Control Module																																																										
W	2016	Cascada	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
W	2016	Cascada	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																										V							
W	2016	Cascada	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
W	2016	Cascada	Body	Passenger Presence Module																																V																											
W	2016	Cascada	Body	Instrument Cluster																																	V																										
W	2016	Cascada	Body	Headlamp Control Module																																																										
W	2016	Cascada	Body	Radio																																																										
W	2016	Cascada	Body	Multimedia Player Interface Module																																	V																										
W	2016	Cascada	Body	Telematics Communication Interface Control Module																																		V	V	V																						
W	2016	Cascada	Body	HVAC Auto Control Dual Zone (CJ2)																														V											V	V	V	V	V											
W	2016	Cascada	Body	HVAC Manual Control Heater Only (C42)																														V												V	V	V	V											
W	2016	Cascada	Body	HVAC Auto Control Single Zone (C68)																														V											V	V	V	V	V											
W	2016	Cascada	Body	Front Seat Heating Control Module																																					V	V																			
W	2016	Cascada	Body	Folding Top Control Module														V																																											
W	2016	Cascada	Body	Parking Assist Control Module																																	V																										
W	2016	Cascada	Body	Frontview Camera Module																																																										
W	2016	Cascada	Body	Power Supply Transformer																																																										

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
G	2010	Lacrosse	Chassis	Steering Wheel Angle Sensor Module																																																													
G	2010	Lacrosse	Chassis	Suspension Control Module																																																													
G	2010	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																													
G	2010	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
G	2010	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																													
G	2010	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																													
G	2010	Lacrosse	Body	Passenger Presence Module																																																													
G	2010	Lacrosse	Body	Instrument Cluster																																																													
G	2010	Lacrosse	Body	Head-Up Display Module																																																													
G	2010	Lacrosse	Body	Headlamp Control Module																																																													
G	2010	Lacrosse	Body	Radio																																																													
G	2010	Lacrosse	Body	Digital Radio Receiver Control Module																																																													
G	2010	Lacrosse	Body	Multimedia Player Interface Module																																																													
G	2010	Lacrosse	Body	Telematics Communication Interface Control Module Version 8																																																													
G	2010	Lacrosse	Body	Telematics Communication Interface Control Module Version 9																																																													
G	2010	Lacrosse	Body	Telematics Communication Interface Control Module Version 10																																																													
G	2010	Lacrosse	Body	HVAC Control Module Auto Dual (CJ2)																																																													
G	2010	Lacrosse	Body	HVAC Control Module Auto Single (C68)																																																													
G	2010	Lacrosse	Body	Seat Memory Control Module																																																													
G	2010	Lacrosse	Body	Front Seat Heating Control Module																																																													
G	2010	Lacrosse	Body	Rear Seat Heating Control Module																																																													
G	2010	Lacrosse	Body	Keyless Entry Control Module																																																													
G	2010	Lacrosse	Body	Right Side Object Detection Control Module																																																												
G	2010	Lacrosse	Body	Left Side Object Detection Control Module																																																												
G	2010	Lacrosse	Body	Parking Assist Control Module																																																												
G	2010	Lacrosse	Body	Steering Column Lock Control Module																																																												
G	2011	Lacrosse	Powertrain	(C) 2.4L LAF Engine Control Module																																																												
G	2011	Lacrosse	Powertrain	(C) 2.4L LAF Fuel Pump Control Module																																																												
G	2011	Lacrosse	Powertrain	(C) 2.4L LAF Transmission Control Module																																																												
G	2011	Lacrosse	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																												
G	2011	Lacrosse	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
G	2011	Lacrosse	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
G	2011	Lacrosse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
G	2011	Lacrosse	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																												
G	2011	Lacrosse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
G	2011	Lacrosse	Powertrain	Rear Differential Clutch Control Module																																																												
G	2011	Lacrosse	Chassis	Electronic Brake Control Module																																																												
G	2011	Lacrosse	Chassis	Parking Brake Control Module																																																												
G	2011	Lacrosse	Chassis	Multi-Axis Acceleration Sensor Module																																																												
G	2011	Lacrosse	Chassis	Power Steering Control Module																																																												
G	2011	Lacrosse	Chassis	Steering Wheel Angle Sensor Module																																																												
G	2011	Lacrosse	Chassis	Suspension Control Module																																																												
G	2011	Lacrosse	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
G	2011	Lacrosse	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
G	2011	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																												
G	2011	Lacrosse	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																												
G	2011	Lacrosse	Body	Passenger Presence Module																																																													
G	2011	Lacrosse	Body	Instrument Cluster																																																													
G	2011	Lacrosse	Body	Head-Up Display Module																																																													
G	2011	Lacrosse	Body	Headlamp Control Module																																																													
G	2011	Lacrosse	Body	Radio																																																													

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
G	2011	Lacrosse	Body	Digital Radio Receiver Control Module																																																											
G	2011	Lacrosse	Body	Multimedia Player Interface Module																																																											
G	2011	Lacrosse	Body	Telematics Communication Interface Control Module Version 8																																																											
G	2011	Lacrosse	Body	Telematics Communication Interface Control Module Version 9																																																											
G	2011	Lacrosse	Body	Telematics Communication Interface Control Module Version 10																																																											
G	2011	Lacrosse	Body	HVAC Control Module Auto Dual (CJ2)																																																											
G	2011	Lacrosse	Body	HVAC Control Module Auto Single (C68)																																																											
G	2011	Lacrosse	Body	Seat Memory Control Module																																																											
G	2011	Lacrosse	Body	Front Seat Heating Control Module																																																											
G	2011	Lacrosse	Body	Rear Seat Heating Control Module																																																											
G	2011	Lacrosse	Body	Keyless Entry Control Module																																																											
G	2011	Lacrosse	Body	Right Side Object Detection Control Module																																																											
G	2011	Lacrosse	Body	Left Side Object Detection Control Module																																																											
G	2011	Lacrosse	Body	Parking Assist Control Module																																																											
G	2011	Lacrosse	Body	Steering Column Lock Control Module																																																											
G	2011	Regal	Powertrain	(V) 2.0L LHU Engine Control Module																																																											
G	2011	Regal	Powertrain	(V) 2.0L LHU Transmission Control Module																																																											
G	2011	Regal	Powertrain	(C) 2.4L LAF Engine Control Module																																																											
G	2011	Regal	Powertrain	(C) 2.4L LAF Transmission Control Module																																																											
G	2011	Regal	Powertrain	Fuel Pump Control Module																																																											
G	2011	Regal	Powertrain	Rear Differential Clutch Control Module																																																											
G	2011	Regal	Chassis	Electronic Brake Control Module																																																											
G	2011	Regal	Chassis	Parking Brake Control Module																																																											
G	2011	Regal	Chassis	Multi-Axis Acceleration Sensor Module																																																											
G	2011	Regal	Chassis	Power Steering Control Module																																																											
G	2011	Regal	Chassis	Steering Wheel Angle Sensor Module																																																											
G	2011	Regal	Chassis	Suspension Control Module																																																											
G	2011	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
G	2011	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
G	2011	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																											
G	2011	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																											
G	2011	Regal	Body	Passenger Presence Module																																																											
G	2011	Regal	Body	Instrument Cluster																																																											
G	2011	Regal	Body	Head-Up Display Module																																																											
G	2011	Regal	Body	Radio																																																											
G	2011	Regal	Body	Digital Radio Receiver Control Module																																																											
G	2011	Regal	Body	Multimedia Player Interface Module																																																											
G	2011	Regal	Body	Telematics Communication Interface Control Module Version 8																																																											
G	2011	Regal	Body	Telematics Communication Interface Control Module Version 9																																																											
G	2011	Regal	Body	Telematics Communication Interface Control Module Version 10																																																											
G	2011	Regal	Body	Remote Heater and Air Conditioning Control Module																																																											
G	2011	Regal	Body	Seat Memory Control Module																																																											
G	2011	Regal	Body	Front Seat Heating Control Module																																																											
G	2011	Regal	Body	Rear Seat Heating Control Module																																																											
G	2011	Regal	Body	Keyless Entry Control Module																																																											
G	2011	Regal	Body	Right Side Object Detection Control Module																																																											
G	2011	Regal	Body	Left Side Object Detection Control Module																																																											
G	2011	Regal	Body	Parking Assist Control Module																																																											
G	2011	Regal	Body	Steering Column Lock Control Module																																																											
G	2012	Lacrosse	Powertrain	(M) 2.4L LAF Engine Control Module																																																											
G	2012	Lacrosse	Powertrain	(M) 2.4L LAF Fuel Pump Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
G	2016	Regal	Chassis	Power Steering Control Module																																																													
G	2016	Regal	Chassis	Steering Wheel Angle Sensor Module																																																												
G	2016	Regal	Chassis	Suspension Control Module																																																												
G	2016	Regal	Body	Body Control Module Headlamp Type Halogen (T4A TT4)									V								V																																										
G	2016	Regal	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)									V								V																																										
G	2016	Regal	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2016	Regal	Body	Passenger Presence Module																																																												
G	2016	Regal	Body	Instrument Cluster																																																											
G	2016	Regal	Body	Radio Controls																																																											
G	2016	Regal	Body	HVAC Controls																																																											
G	2016	Regal	Body	Radio																		V	V																																								
G	2016	Regal	Body	Amplifier																				V	V																																						
G	2016	Regal	Body	Infotainment Control Touchpad																																																												
G	2016	Regal	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																		
G	2016	Regal	Body	Telematics Communication Interface Control Module Version 9.7																																																												
G	2016	Regal	Body	Telematics Communication Interface Control Module Version 10																																																												
G	2016	Regal	Body	HVAC Control Module																																																												
G	2016	Regal	Body	Seat Memory Control Module - Driver																																																												
G	2016	Regal	Body	Front Seat Heating Control Module																																																												
G	2016	Regal	Body	Keyless Entry Control Module																																																												
G	2016	Regal	Body	Left Side Object Detection Control Module																																																												
G	2016	Regal	Body	Parking Assist Control Module																																																												
G	2016	Regal	Body	Frontview Camera Module																											V	V																																
G	2016	Regal	Body	Battery Energy Control Module				V	V	V																																																					
P	2012	Verano	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
P	2012	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
P	2012	Verano	Powertrain	Fuel Pump Control Module																																																												
P	2012	Verano	Chassis	Electronic Brake Control Module																																																												
P	2012	Verano	Chassis	Parking Brake Control Module																																																												
P	2012	Verano	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2012	Verano	Chassis	Power Steering Control Module																																																												
P	2012	Verano	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2012	Verano	Body	Body Control Module																																																												
P	2012	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2012	Verano	Body	Passenger Presence Module																																																												
P	2012	Verano	Body	Instrument Cluster																																																												
P	2012	Verano	Body	Headlamp Control Module																															V																													
P	2012	Verano	Body	Radio																																																											
P	2012	Verano	Body	Telematics Communication Interface Control Module Version 8																																																												
P	2012	Verano	Body	Telematics Communication Interface Control Module Version 9																																																												
P	2012	Verano	Body	Telematics Communication Interface Control Module Version 10																																																												
P	2012	Verano	Body	HVAC Control Module Auto Dual (CJ2)																																																												
P	2012	Verano	Body	HVAC Control Module Manual Single (C67)																																																												
P	2012	Verano	Body	Front Seat Heating Control Module																																																												
P	2012	Verano	Body	Keyless Entry Control Module																																																												
P	2012	Verano	Body	Parking Assist Control Module																																																												
P	2013	Verano	Powertrain	(V) 2.0L LHU Engine Control Module Automatic Transmission																																																												
P	2013	Verano	Powertrain	(V) 2.0L LHU Engine Control Module Manual Transmission																																																												
P	2013	Verano	Powertrain	(V) 2.0L LHU Transmission Control Module																																																												
P	2013	Verano	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
P	2013	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
P	2013	Verano	Powertrain	Fuel Pump Control Module																																																											
P	2013	Verano	Chassis	Electronic Brake Control Module											V	V	V	V	V																																												
P	2013	Verano	Chassis	Parking Brake Control Module																																																											
P	2013	Verano	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2013	Verano	Chassis	Power Steering Control Module																																																											
P	2013	Verano	Chassis	Power Steering Control Module																																																											
P	2013	Verano	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2013	Verano	Body	Body Control Module									V																																																	
P	2013	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2013	Verano	Body	Passenger Presence Module																																																											
P	2013	Verano	Body	Instrument Cluster																																																											
P	2013	Verano	Body	Radio																																																											
P	2013	Verano	Body	Multimedia Player Interface Module																																																											
P	2013	Verano	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2013	Verano	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2013	Verano	Body	HVAC Control Module Auto Dual (CJ2)																																																											
P	2013	Verano	Body	HVAC Control Module Manual Single (C67)																																																											
P	2013	Verano	Body	Front Seat Heating Control Module																																																											
P	2013	Verano	Body	Keyless Entry Control Module																																																											
P	2013	Verano	Body	Right Side Object Detection Control Module																																																											
P	2013	Verano	Body	Left Side Object Detection Control Module																																																											
P	2013	Verano	Body	Parking Assist Control Module																																																											
P	2014	Verano	Powertrain	(V) 2.0L LHU Engine Control Module Automatic Transmission																																																											
P	2014	Verano	Powertrain	(V) 2.0L LHU Engine Control Module Manual Transmission																																																											
P	2014	Verano	Powertrain	(V) 2.0L LHU Transmission Control Module																																																											
P	2014	Verano	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
P	2014	Verano	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
P	2014	Verano	Powertrain	Fuel Pump Control Module																																																											
P	2014	Verano	Chassis	Electronic Brake Control Module																																																											
P	2014	Verano	Chassis	Parking Brake Control Module																																																											
P	2014	Verano	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2014	Verano	Chassis	Power Steering Control Module																																																											
P	2014	Verano	Chassis	Power Steering Control Module																																																											
P	2014	Verano	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2014	Verano	Body	Body Control Module									V																																																	
P	2014	Verano	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2014	Verano	Body	Passenger Presence Module																																																											
P	2014	Verano	Body	Instrument Cluster																																																											
P	2014	Verano	Body	Radio																																																											
P	2014	Verano	Body	Multimedia Player Interface Module																																																											
P	2014	Verano	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2014	Verano	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2014	Verano	Body	HVAC Control Module Auto Dual (CJ2)																																																											
P	2014	Verano	Body	HVAC Control Module Manual Single (C67)																																																											
P	2014	Verano	Body	Front Seat Heating Control Module																																																											
P	2014	Verano	Body	Keyless Entry Control Module																																																											
P	2014	Verano	Body	Left Side Object Detection Control Module																																																											
P	2014	Verano	Body	Parking Assist Control Module																																																											
P	2014	Verano	Body	Frontview Camera Module																											V	V																															
P	2015	Verano	Powertrain	(V) 2.0L LHU Engine Control Module																																																											
P	2015	Verano	Powertrain	(V) 2.0L LHU Transmission Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
P	2016	Verano	Body	Parking Assist Control Module																																																											
P	2016	Verano	Body	Frontview Camera Module																											V	V																														
W	2016	Cascada	Powertrain	(5) 1.6L LWC Engine Control Module																													V		V																											
W	2016	Cascada	Powertrain	(5) 1.6L LWC Transmission Control Module																																																									
W	2016	Cascada	Chassis	Electronic Brake Control Module											V	V	V	V	V																																										
W	2016	Cascada	Chassis	Parking Brake Control Module																																																									
W	2016	Cascada	Chassis	Multi-Axis Acceleration Sensor Module																																																									
W	2016	Cascada	Chassis	Power Steering Control Module																																V																									
W	2016	Cascada	Chassis	Steering Wheel Angle Sensor Module																																																									
W	2016	Cascada	Body	Body Control Module									V																								V	V																						
W	2016	Cascada	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
W	2016	Cascada	Body	Passenger Presence Module																																																									
W	2016	Cascada	Body	Instrument Cluster																																																									
W	2016	Cascada	Body	Headlamp Control Module																															V				V																					
W	2016	Cascada	Body	Radio																																																									
W	2016	Cascada	Body	Multimedia Player Interface Module																																																									
W	2016	Cascada	Body	Telematics Communication Interface Control Module																																																									
W	2016	Cascada	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
W	2016	Cascada	Body	HVAC Manual Control Heater Only (C42)																																																									
W	2016	Cascada	Body	HVAC Auto Control Single Zone (C68)																																																									
W	2016	Cascada	Body	Front Seat Heating Control Module																																																									
W	2016	Cascada	Body	Folding Top Control Module																																					V	V																			
W	2016	Cascada	Body	Parking Assist Control Module																																							V	V	V															
W	2016	Cascada	Body	Frontview Camera Module																											V	V																												
W	2016	Cascada	Body	Power Supply Transformer																																																								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V													V															
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission	V																			V	V	V	V		V	V	V	V													V	V														
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump	V	V																		V	V							V		V																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter	V	V									V									V	V							V																												
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Engine Mount	V	V																		V	V							V																												
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Active Grile Air Shutter And Engine Mount	V	V																		V	V							V																												
A	2013	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																		V	V										V	V	V	V									V													
A	2013	ATS	Powertrain	(A) 2.5L LCV Engine Control Module	V																			V	V	V	V	V	V	V		V	V																											
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump	V	V																		V	V							V		V																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter	V	V									V									V	V							V																												
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Engine Mount	V	V																		V	V							V																												
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Active Grile Air Shutter And Engine Mount	V	V																		V	V							V																												
A	2013	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V										V	V	V	V									V													
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V								V	V	V	V		V													
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V									V	V	V	V	V	V													
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump	V	V																		V	V							V		V																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter	V	V									V									V	V							V																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Engine Mount	V	V																		V	V							V																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Active Grile Air Shutter And Engine Mount	V	V																		V	V							V																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V													
A	2013	ATS	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
A	2013	ATS	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
A	2013	ATS	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
A	2013	ATS	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		
A	2013	ATS	Chassis	Power Steering Control Module	V	V																			V																																		
A	2013	ATS	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
A	2013	ATS	Chassis	Suspension Control Module	V	V																		V	V																																		
A	2013	ATS	Body	Body Control Module Halogen	V	V																		V	V																																		
A	2013	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
A	2013	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
A	2013	ATS	Body	Passenger Presence Module	V	V																			V																																		
A	2013	ATS	Body	Pedestrian Impact Detection Module	V	V																			V																																		
A	2013	ATS	Body	Instrument Cluster	V	V																		V	V																																		
A	2013	ATS	Body	Radio/HVAC Control	V																																																					
A	2013	ATS	Body	Active Safety Control Module	V	V																		V	V																					V													
A	2013	ATS	Body	Headlamp Control Module	V	V																		V	V																					V													
A	2013	ATS	Body	Trailer Interface Control Module	V	V																		V	V																																		
A	2013	ATS	Body	Radio	V	V																		V	V																																		
A	2013	ATS	Body	Amplifier	V	V																			V																																		
A	2013	ATS	Body	Human Machine Interface Control Module	V	V																		V	V																					V													
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
A	2013	ATS	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
A	2013	ATS	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																		
A	2013	ATS	Body	Seat Memory Control Module	V																																																					
A	2013	ATS	Body	Keyless Entry Type Without Passive Entry	V																				V																																		
A	2013	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)	V	V																		V	V																																		
A	2013	ATS	Body	Right Side Object Detection Control Module	V																			V	V																																		
A	2013	ATS	Body	Left Side Object Detection Control Module	V																			V	V																																		
A	2013	ATS	Body	Parking Assist Control Module	V	V																		V	V																																		
A	2013	ATS	Body	Frontview Camera Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2013	ATS	Body	Steering Column Lock Control Module	V	V																			V																																			
A	2013	ATS	Body	Long Range Radar Sensor Module	V	V																			V																																			
A	2013	ATS	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
A	2013	ATS	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
A	2013	ATS	Body	Rear Short Range Radar Sensor Module	V																				V																																			
A	2014	ATS	Powertrain	(X) 2.0L LTG Engine Control Module	V																		V	V	V	V		V	V	V	V	V												V	V														
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump	V	V																	V	V							V																													
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter	V	V									V								V	V							V																													
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount	V	V									V								V	V							V																													
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount	V	V									V								V	V							V																													
A	2014	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																	V	V										V	V	V	V								V															
A	2014	ATS	Powertrain	(A) 2.5L LCV Engine Control Module	V																		V	V	V	V	V	V	V		V	V																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump	V	V																	V	V							V																													
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter	V	V									V								V	V							V																													
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount	V	V									V								V	V							V																													
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount	V	V									V								V	V							V																													
A	2014	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																	V	V										V	V	V	V								V															
A	2014	ATS	Powertrain	(3) 3.6L LFX Engine Control Module	V																		V	V				V	V	V	V	V								V	V	V	V	V	V														
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump	V	V																	V	V							V																													
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter	V	V									V								V	V							V																													
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount	V	V									V								V	V							V																													
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount	V	V									V								V	V							V																													
A	2014	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																	V	V										V	V	V	V								V															
A	2014	ATS	Powertrain	Transfer Case Control Module	V	V																	V	V																																				
A	2014	ATS	Chassis	Electronic Brake Control Module	V	V																	V	V												V										V	V	V	V	V	V								
A	2014	ATS	Chassis	Parking Brake Control Module	V	V																		V																					V							V	V	V	V				
A	2014	ATS	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																			
A	2014	ATS	Chassis	Power Steering Control Module	V	V																		V																																				
A	2014	ATS	Chassis	Steering Wheel Angle Sensor Module	V																			V																																				
A	2014	ATS	Chassis	Suspension Control Module	V	V																	V	V																																				
A	2014	ATS	Body	Body Control Module Halogen	V	V																	V	V																																				
A	2014	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																	V	V																																				
A	2014	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																				
A	2014	ATS	Body	Passenger Presence Module	V	V																		V																																				
A	2014	ATS	Body	Pedestrian Impact Detection Module	V	V																		V																																				
A	2014	ATS	Body	Instrument Cluster	V	V																	V	V																																				
A	2014	ATS	Body	Radio/HVAC Control	V																																																							
A	2014	ATS	Body	Active Safety Control Module	V	V																	V	V																						V														
A	2014	ATS	Body	Headlamp Control Module	V	V																	V	V																						V														
A	2014	ATS	Body	Trailer Interface Control Module	V	V																	V	V																																				
A	2014	ATS	Body	Radio	V	V																	V	V																																				
A	2014	ATS	Body	Amplifier	V	V																		V																																				
A	2014	ATS	Body	Media Disc Player	V	V																	V	V																																				
A	2014	ATS	Body	Human Machine Interface Control Module	V	V																	V	V																						V														
A	2014	ATS	Body	Navigation Control Module	V	V																		V																																				
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 9	V	V																	V	V																																				
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																				
A	2014	ATS	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																	V	V																																				
A	2014	ATS	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																	V	V																																				
A	2014	ATS	Body	Seat Memory Control Module - Driver	V																																																							
A	2014	ATS	Body	Keyless Entry Type Without Passive Entry	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2014	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)	V	V																		V	V																																			
A	2014	ATS	Body	Right Side Object Detection Control Module	V																			V	V																																			
A	2014	ATS	Body	Left Side Object Detection Control Module	V																			V	V																																			
A	2014	ATS	Body	Parking Assist Control Module	V	V																		V	V																																			
A	2014	ATS	Body	Frontview Camera Module	V	V																		V	V																																			
A	2014	ATS	Body	Steering Column Lock Control Module	V	V																			V																																			
A	2014	ATS	Body	Long Range Radar Sensor Module	V	V																			V																																			
A	2014	ATS	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
A	2014	ATS	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
A	2014	ATS	Body	Rear Short Range Radar Sensor Module	V																				V																																			
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V												V	V													
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Maunal Transmission	V																			V	V	V	V		V	V	V	V												V	V													
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount	V	V									V									V	V							V																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount	V	V									V									V	V							V																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																		V	V										V	V	V	V									V												
A	2014	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
A	2014	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount	V	V																		V	V																																			
A	2014	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module	V	V																		V	V										V	V	V	V																						
A	2014	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module	V	V																		V	V																						V												
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V									V	V	V	V	V	V													
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed	V	V																		V	V										V	V	V	V									V												
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed	V	V																		V	V										V	V	V	V																					
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount	V	V									V									V	V							V																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount	V	V									V									V	V							V																											
A	2014	CTS	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
A	2014	CTS	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						V
A	2014	CTS	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
A	2014	CTS	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
A	2014	CTS	Chassis	Power Steering Control Module	V	V																			V																																			
A	2014	CTS	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
A	2014	CTS	Chassis	Suspension Control Module	V	V																		V	V																																			
A	2014	CTS	Body	Body Control Module Headlamp Type Halogen	V	V																		V	V																																			
A	2014	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
A	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
A	2014	CTS	Body	Passenger Presence Module	V	V																			V																																			
A	2014	CTS	Body	Pedestrian Impact Detection Module	V	V																			V																																			
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Left	V	V																			V																																			
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Right	V	V																			V																																			
A	2014	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																		V	V																																			
A	2014	CTS	Body	Instrument Cluster Full Screen Display (UDV)	V	V																		V	V																																			
A	2014	CTS	Body	Radio/HVAC Control	V																				V																																			
A	2014	CTS	Body	Active Safety Control Module	V	V																		V	V																					V														
A	2014	CTS	Body	Headlamp Control Module	V	V																		V	V																					V														
A	2014	CTS	Body	Trailer Interface Control Module	V	V																		V	V																																			
A	2014	CTS	Body	Radio	V	V																		V	V																																			
A	2014	CTS	Body	Amplifier	V	V																			V																																			
A	2014	CTS	Body	Human Machine Interface Control Module	V	V																		V	V																					V														
A	2014	CTS	Body	Navigation Control Module	V	V																			V																																			
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2014	CTS	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
A	2014	CTS	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																		
A	2014	CTS	Body	Seat Memory Control Module - Driver	V																																																						
A	2014	CTS	Body	Keyless Entry Control Module	V	V																		V	V																																		
A	2014	CTS	Body	Right Side Object Detection Control Module	V																			V	V																																		
A	2014	CTS	Body	Left Side Object Detection Control Module	V																			V	V																																		
A	2014	CTS	Body	Parking Assist Control Module	V																			V	V																																		
A	2014	CTS	Body	Frontview Camera Module	V	V																		V	V																																		
A	2014	CTS	Body	Steering Column Lock Control Module	V	V																			V																																		
A	2014	CTS	Body	Long Range Radar Sensor Module	V	V																			V																																		
A	2014	CTS	Body	Left Front Short Range Radar Sensor Module	V																				V																																		
A	2014	CTS	Body	Right Front Short Range Radar Sensor Module	V																				V																																		
A	2014	CTS	Body	Rear Short Range Radar Sensor Module	V																				V																																		
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V													V												
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission	V																			V	V	V	V		V	V	V	V												V	V												
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump	V	V																		V	V							V																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter	V	V									V									V	V							V																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount	V	V									V									V	V							V																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount	V	V									V									V	V							V																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																		V	V										V	V	V	V									V												
A	2015	ATS	Powertrain	(A) 2.5L LCV Engine Control Module	V																			V	V	V	V	V	V	V		V	V																									
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump	V	V																		V	V							V																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter	V	V									V									V	V							V																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount	V	V									V									V	V							V																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount	V	V									V									V	V							V																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V										V	V	V	V									V												
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V								V	V	V	V		V												
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V									V	V	V	V	V	V												
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump	V	V																		V	V							V																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter	V	V									V									V	V							V																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount	V	V									V									V	V							V																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount	V	V									V									V	V							V																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V												
A	2015	ATS	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
A	2015	ATS	Chassis	Electronic Brake Control Module	V	V																		V	V													V											V	V	V	V	V	V						
A	2015	ATS	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
A	2015	ATS	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		
A	2015	ATS	Chassis	Power Steering Control Module	V	V																			V																																		
A	2015	ATS	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
A	2015	ATS	Chassis	Suspension Control Module	V	V																		V	V																																		
A	2015	ATS	Body	Body Control Module Halogen	V	V																		V	V																																		
A	2015	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
A	2015	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
A	2015	ATS	Body	Passenger Presence Module	V	V																			V																																		
A	2015	ATS	Body	Pedestrian Impact Detection Module	V	V																			V																																		
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Left	V	V																			V																																		
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Right	V	V																			V																																		
A	2015	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																		V	V																																		
A	2015	ATS	Body	Instrument Cluster Full Screen Display (UDV)	V	V																		V	V																																		
A	2015	ATS	Body	Radio/HVAC Control	V																				V																																		
A	2015	ATS	Body	Active Safety Control Module	V	V																		V	V																						V												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2015	ATS	Body	Headlamp Control Module	V	V																		V	V																					V													
A	2015	ATS	Body	Trailer Interface Control Module	V	V																		V	V																																		
A	2015	ATS	Body	Radio	V	V																		V	V																																		
A	2015	ATS	Body	Amplifier	V	V																			V																																		
A	2015	ATS	Body	Media Disc Player	V	V																		V	V																																		
A	2015	ATS	Body	Human Machine Interface Control Module	V	V																		V	V																					V													
A	2015	ATS	Body	Navigation Control Module	V	V																			V																																		
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
A	2015	ATS	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
A	2015	ATS	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																		
A	2015	ATS	Body	Seat Memory Control Module - Driver	V																																																					
A	2015	ATS	Body	Keyless Entry Control Module Coupe	V	V																		V	V																																		
A	2015	ATS	Body	Keyless Entry Control Module Sadan	V	V																		V	V																																		
A	2015	ATS	Body	Right Side Object Detection Control Module	V																			V	V																																		
A	2015	ATS	Body	Left Side Object Detection Control Module	V																			V	V																																		
A	2015	ATS	Body	Parking Assist Control Module	V	V																		V	V																																		
A	2015	ATS	Body	Frontview Camera Module	V	V																			V																																		
A	2015	ATS	Body	Steering Column Lock Control Module	V	V																			V																																		
A	2015	ATS	Body	Long Range Radar Sensor Module	V	V																			V																																		
A	2015	ATS	Body	Left Front Short Range Radar Sensor Module	V																				V																																		
A	2015	ATS	Body	Right Front Short Range Radar Sensor Module	V																				V																																		
A	2015	ATS	Body	Rear Short Range Radar Sensor Module	V																				V																																		
A	2015	CTS	Powertrain	(X) 2.0L LTG Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V	V													
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Engine Mount	V	V																		V	V																																		
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount	V	V									V									V	V							V																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount	V	V									V									V	V							V																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																		V	V									V	V	V	V									V													
A	2015	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount	V	V																		V	V																																		
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Fuel Pump and Engine Mount	V	V									V									V	V							V																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Active Grile Air Shutter And Engine Mount	V	V									V									V	V							V																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module	V	V																		V	V									V	V	V	V																					
A	2015	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module	V	V																		V	V																					V												
A	2015	CTS	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Engine Mount	V	V																		V	V																																		
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount	V	V									V									V	V							V																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount	V	V									V									V	V							V																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V													
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V																					
A	2015	CTS	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
A	2015	CTS	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
A	2015	CTS	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
A	2015	CTS	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		
A	2015	CTS	Chassis	Power Steering Control Module	V	V																			V																																		
A	2015	CTS	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
A	2015	CTS	Chassis	Suspension Control Module	V	V																		V	V																																		
A	2015	CTS	Body	Body Control Module Headlamp Type Halogen	V	V																		V	V																																		
A	2015	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
A	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
A	2015	CTS	Body	Passenger Presence Module	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2015	CTS	Body	Pedestrian Impact Detection Module	V	V																			V																																			
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Left	V	V																			V																																			
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Right	V	V																			V																																			
A	2015	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																		V	V																																			
A	2015	CTS	Body	Instrument Cluster Full Screen Display (UDV)	V	V																		V	V																																			
A	2015	CTS	Body	Active Safety Control Module	V	V																		V	V																							V											
A	2015	CTS	Body	Trailer Interface Control Module	V	V																		V	V																																			
A	2015	CTS	Body	Radio	V	V																		V	V																																			
A	2015	CTS	Body	Amplifier	V	V																			V																																			
A	2015	CTS	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
A	2015	CTS	Body	Navigation Control Module	V	V																			V																																			
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
A	2015	CTS	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
A	2015	CTS	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																			
A	2015	CTS	Body	Seat Memory Control Module - Driver	V																																																							
A	2015	CTS	Body	Keyless Entry Control Module	V	V																		V	V																																			
A	2015	CTS	Body	Right Side Object Detection Control Module	V																			V	V																																			
A	2015	CTS	Body	Left Side Object Detection Control Module	V																			V	V																																			
A	2015	CTS	Body	Parking Assist Control Module	V																			V	V																																			
A	2015	CTS	Body	Frontview Camera Module	V	V																			V																																			
A	2015	CTS	Body	Steering Column Lock Control Module	V	V																			V																																			
A	2015	CTS	Body	Long Range Radar Sensor Module	V	V																			V																																			
A	2015	CTS	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
A	2015	CTS	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
A	2015	CTS	Body	Rear Short Range Radar Sensor Module	V																				V																																			
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V														
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V													V														
A	2016	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																		V	V										V	V	V	V		V																				
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V														
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V													V														
A	2016	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V										V	V	V	V										V													
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V	V														
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V													V														
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Transmission Control Module	V	V																		V	V										V	V	V	V		V																				
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V								V	V	V	V		V														
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V								V	V	V	V	V	V														
A	2016	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V		V																				
A	2016	ATS	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
A	2016	ATS	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																							V												
A	2016	ATS	Chassis	Electronic Brake Control Module	V	V																		V	V													V											V	V	V	V	V	V							
A	2016	ATS	Chassis	Parking Brake Control Module	V	V																			V																						V									V	V	V	V			
A	2016	ATS	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
A	2016	ATS	Chassis	Power Steering Control Module	V	V																			V																																			
A	2016	ATS	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
A	2016	ATS	Chassis	Suspension Control Module	V	V																		V	V																																			
A	2016	ATS	Body	Body Control Module Halogen	V	V																		V	V																																			
A	2016	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
A	2016	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
A	2016	ATS	Body	Passenger Presence Module	V	V																			V																																			
A	2016	ATS	Body	Pedestrian Impact Detection Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Left	V	V																			V																																			
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Right	V	V																			V																																			
A	2016	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																		V	V																																			
A	2016	ATS	Body	Instrument Cluster Full Screen Display (UDV)	V	V																		V	V																																			
A	2016	ATS	Body	Radio/HVAC Control	V																				V																																			
A	2016	ATS	Body	Vehicle Performance Data Recorder	V																				V																																			
A	2016	ATS	Body	Trailer Interface Control Module	V	V																		V	V																																			
A	2016	ATS	Body	Radio	V	V																		V	V																																			
A	2016	ATS	Body	Amplifier	V	V																			V																																			
A	2016	ATS	Body	Rear Audio Control Module	V	V																		V	V																																			
A	2016	ATS	Body	Media Disc Player	V	V																		V	V																																			
A	2016	ATS	Body	Human Machine Interface Control Module	V	V																		V	V																								V											
A	2016	ATS	Body	Navigation Control Module	V	V																			V																																			
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
A	2016	ATS	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
A	2016	ATS	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																			
A	2016	ATS	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
A	2016	ATS	Body	Seat Memory Control Module - Driver	V																																																							
A	2016	ATS	Body	Keyless Entry Control Module Coupe	V	V																		V	V																																			
A	2016	ATS	Body	Keyless Entry Control Module Sadan	V	V																		V	V																																			
A	2016	ATS	Body	Right Side Object Detection Control Module	V																			V	V																																			
A	2016	ATS	Body	Left Side Object Detection Control Module	V																			V	V																																			
A	2016	ATS	Body	Parking Assist Control Module	V	V																		V	V																																			
A	2016	ATS	Body	Frontview Camera Module	V	V																		V	V																																			
A	2016	ATS	Body	Steering Column Lock Control Module	V	V																			V																																			
A	2016	ATS	Body	Long Range Radar Sensor Module	V	V																			V																																			
A	2016	ATS	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
A	2016	ATS	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
A	2016	ATS	Body	Rear Short Range Radar Sensor Module	V																				V																																			
A	2016	CTS	Powertrain	(X) 2.0L LTG Engine Control Module	V																			V	V				V	V	V	V	V													V													
A	2016	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																		V	V										V	V	V	V		V																			
A	2016	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module	V																			V	V				V	V	V	V	V												V	V												
A	2016	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module	V	V																		V	V										V	V	V	V																					
A	2016	CTS	Powertrain	(S) 3.6L LGX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V												
A	2016	CTS	Powertrain	(S) 3.6L LGX Transmission Control Module	V	V																		V	V										V	V	V	V		V																			
A	2016	CTS	Powertrain	(6) 6.2L LT4 Engine Control Module	V																			V	V				V	V	V	V	V												V													
A	2016	CTS	Powertrain	(6) 6.2L LT4 Transmission Control Module	V	V																		V	V										V	V	V	V		V																			
A	2016	CTS	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																								V											
A	2016	CTS	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
A	2016	CTS	Chassis	Electronic Brake Control Module	V	V																		V	V													V												V	V	V	V	V	V						V
A	2016	CTS	Chassis	Parking Brake Control Module	V	V																			V																							V							V	V	V	V			
A	2016	CTS	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
A	2016	CTS	Chassis	Power Steering Control Module	V	V																			V																																			
A	2016	CTS	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
A	2016	CTS	Chassis	Suspension Control Module	V	V																		V	V																																			
A	2016	CTS	Body	Body Control Module Headlamp Type Halogen	V	V																		V	V																																			
A	2016	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
A	2016	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
A	2016	CTS	Body	Passenger Presence Module	V	V																			V																																			
A	2016	CTS	Body	Pedestrian Impact Detection Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Left	V	V																			V																																			
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Right	V	V																			V																																			
A	2016	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																		V	V																																			
A	2016	CTS	Body	Instrument Cluster Full Screen Display (UDV)	V	V																		V	V																																			
A	2016	CTS	Body	Radio/HVAC Control	V																				V																																			
A	2016	CTS	Body	Vehicle Performance Data Recorder	V																				V																																			
A	2016	CTS	Body	Active Safety Control Module	V	V																		V	V																						V													
A	2016	CTS	Body	Video Processing Control Module	V	V																		V	V																																			
A	2016	CTS	Body	Trailer Interface Control Module	V	V																		V	V																																			
A	2016	CTS	Body	Radio	V	V																		V	V																																			
A	2016	CTS	Body	Amplifier	V	V																			V																																			
A	2016	CTS	Body	Human Machine Interface Control Module	V	V																		V	V																						V													
A	2016	CTS	Body	Navigation Control Module	V	V																			V																																			
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
A	2016	CTS	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
A	2016	CTS	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																			
A	2016	CTS	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
A	2016	CTS	Body	Seat Memory Control Module - Driver	V																																																							
A	2016	CTS	Body	Keyless Entry Control Module	V	V																		V	V																																			
A	2016	CTS	Body	Right Side Object Detection Control Module	V																			V	V																																			
A	2016	CTS	Body	Left Side Object Detection Control Module	V																			V	V																																			
A	2016	CTS	Body	Parking Assist Control Module	V																			V	V																																			
A	2016	CTS	Body	Frontview Camera Module	V	V																		V	V																																			
A	2016	CTS	Body	Steering Column Lock Control Module	V	V																			V																																			
A	2016	CTS	Body	Long Range Radar Sensor Module	V	V																			V																																			
A	2016	CTS	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
A	2016	CTS	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
A	2016	CTS	Body	Rear Short Range Radar Sensor Module	V																				V																																			
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto	V	V							V			V					V	V		V	V							V																												
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual	V	V							V			V					V	V		V	V							V																												
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module	V	V																		V	V										V	V																							
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto	V	V							V			V					V	V		V	V							V																												
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual	V	V							V			V					V	V		V	V							V																												
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module	V	V																		V	V										V	V																							
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V			V				V			V	V				V	V		V	V							V																												
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V											V	V																							
D	2004	(DM)CTS	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																			
D	2004	(DM)CTS	Chassis	VES	V	V																		V																																				
D	2004	(DM)CTS	Body	Amplifier (Bose)	V	V																																																						
D	2004	(DM)CTS	Body	Amplifier (Delco)	V	V																		V																																				
D	2004	(DM)CTS	Body	Climate Control Panel	V	V																		V																																				
D	2004	(DM)CTS	Body	Dash Integration Module	V	V																		V																																				
D	2004	(DM)CTS	Body	Digital Radio Receiver	V	V																			V																																				
D	2004	(DM)CTS	Body	Driver Door Switch	V	V																																																					
D	2004	(DM)CTS	Body	Driver Door Module	V	V																		V																																				
D	2004	(DM)CTS	Body	Passenger Door Module	V	V																		V																																				
D	2004	(DM)CTS	Body	Left Rear Door Module	V	V																		V																																				
D	2004	(DM)CTS	Body	Right Rear Door Module	V	V																		V																																				
D	2004	(DM)CTS	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2004	(DM)CTS	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2004	(DM)CTS	Body	Instrument Panel Cluster	V	V																		V																																					
D	2004	(DM)CTS	Body	Memory Seat Module	V	V																		V																																					
D	2004	(DM)CTS	Body	Personalization																																																									
D	2004	(DM)CTS	Body	Rear Integration Module	V	V																		V																																					
D	2004	(DM)CTS	Body	Remote Function Actuation	V	V																																																							
D	2004	(DM)CTS	Body	Supplemental Inflatable Restraint	V	V																																																							
D	2004	(DM)CTS	Body	TV Antenna Module	V	V																		V																																					
D	2004	(DM)CTS	Body	Vehicle Theft Deterrent	V	V																																																							
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto	V	V							V			V					V	V		V	V							V																													
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual	V	V							V			V					V	V		V	V							V																													
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module	V	V																		V	V									V	V																									
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto	V	V							V			V					V	V		V	V							V																													
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual	V	V							V			V					V	V		V	V							V																													
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module	V	V																		V	V									V	V																									
D	2004	(DR)CTS	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																				
D	2004	(DR)CTS	Chassis	VES	V	V																		V																																					
D	2004	(DR)CTS	Body	Amplifier (Bose)	V	V																																																							
D	2004	(DR)CTS	Body	Amplifier (Delco)	V	V																		V																																					
D	2004	(DR)CTS	Body	Climate Control Panel	V	V																		V																																					
D	2004	(DR)CTS	Body	Dash Integration Module	V	V																		V																																					
D	2004	(DR)CTS	Body	Digital Radio Receiver	V	V																			V																																				
D	2004	(DR)CTS	Body	Driver Door Switch	V	V																																																							
D	2004	(DR)CTS	Body	Driver Door Module	V	V																		V																																					
D	2004	(DR)CTS	Body	Passenger Door Module	V	V																		V																																					
D	2004	(DR)CTS	Body	Left Rear Door Module	V	V																		V																																					
D	2004	(DR)CTS	Body	Right Rear Door Module	V	V																		V																																					
D	2004	(DR)CTS	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																				
D	2004	(DR)CTS	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																				
D	2004	(DR)CTS	Body	Instrument Panel Cluster	V	V																		V																																					
D	2004	(DR)CTS	Body	Memory Seat Module	V	V																		V																																					
D	2004	(DR)CTS	Body	Personalization																																																									
D	2004	(DR)CTS	Body	Rear Integration Module	V	V																		V																																					
D	2004	(DR)CTS	Body	Remote Function Actuation	V	V																																																							
D	2004	(DR)CTS	Body	Supplemental Inflatable Restraint	V	V																																																							
D	2004	(DR)CTS	Body	TV Antenna Module	V	V																		V																																					
D	2004	(DR)CTS	Body	Vehicle Theft Deterrent	V	V																																																							
D	2004	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module	V	V										V	V				V	V		V	V							V														V															
D	2004	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																				
D	2004	(DN)CTS-V	Chassis	Tire Pressure Monitor	V	V																		V																																					
D	2004	(DN)CTS-V	Chassis	VES	V	V																		V																																					
D	2004	(DN)CTS-V	Body	Amplifier (Bose)	V	V																																																							
D	2004	(DN)CTS-V	Body	Amplifier (Delco)	V	V																		V																																					
D	2004	(DN)CTS-V	Body	Climate Control Panel	V	V																		V																																					
D	2004	(DN)CTS-V	Body	Dash Integration Module	V	V																		V																																					
D	2004	(DN)CTS-V	Body	Digital Radio Receiver	V	V																			V																																				
D	2004	(DN)CTS-V	Body	Driver Door Switch	V	V																																																							
D	2004	(DN)CTS-V	Body	Driver Door Module	V	V																		V																																					
D	2004	(DN)CTS-V	Body	Passenger Door Module	V	V																		V																																					
D	2004	(DN)CTS-V	Body	Left Rear Door Module	V	V																		V																																					
D	2004	(DN)CTS-V	Body	Right Rear Door Module	V	V																		V																																					
D	2004	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2004	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																				
D	2004	(DN)CTS-V	Body	Instrument Panel Cluster	V	V																		V																																				
D	2004	(DN)CTS-V	Body	Memory Seat Module	V	V																		V																																				
D	2004	(DN)CTS-V	Body	Personalization																																																							
D	2004	(DN)CTS-V	Body	Rear Integration Module	V	V																		V																																				
D	2004	(DN)CTS-V	Body	Remote Control Door Lock Receiver	V	V																																																					
D	2004	(DN)CTS-V	Body	Supplemental Inflatable Restraint	V	V																																																					
D	2004	(DN)CTS-V	Body	TV Antenna Module	V	V																		V																																				
D	2004	(DN)CTS-V	Body	Vehicle Theft Deterrent	V	V																																																					
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module	V	V			V				V			V	V				V	V		V	V						V																												
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module	V	V																		V										V	V																								
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V			V				V			V	V				V	V		V	V						V																												
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V																								
D	2005	(DM)CTS	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																		
D	2005	(DM)CTS	Chassis	VES	V	V																		V																																				
D	2005	(DM)CTS	Body	Amplifier (Bose)	V	V																																																					
D	2005	(DM)CTS	Body	Amplifier (Delco)	V	V																		V																																				
D	2005	(DM)CTS	Body	Climate Control Panel	V	V																		V																																				
D	2005	(DM)CTS	Body	Dash Integration Module	V	V																		V																																				
D	2005	(DM)CTS	Body	Digital Radio Receiver	V	V																			V																																			
D	2005	(DM)CTS	Body	Driver Door Switch	V	V																																																					
D	2005	(DM)CTS	Body	Driver Door Module	V	V																		V																																				
D	2005	(DM)CTS	Body	Passenger Door Module	V	V																		V																																				
D	2005	(DM)CTS	Body	Left Rear Door Module	V	V																		V																																				
D	2005	(DM)CTS	Body	Right Rear Door Module	V	V																		V																																				
D	2005	(DM)CTS	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2005	(DM)CTS	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2005	(DM)CTS	Body	Instrument Panel Cluster	V	V																		V																																				
D	2005	(DM)CTS	Body	Memory Seat Module	V	V																		V																																				
D	2005	(DM)CTS	Body	Personalization																																																							
D	2005	(DM)CTS	Body	Rear Integration Module	V	V																		V																																				
D	2005	(DM)CTS	Body	Remote Control Door Lock Receiver	V	V																																																					
D	2005	(DM)CTS	Body	Supplemental Inflatable Restraint	V	V																																																					
D	2005	(DM)CTS	Body	TV Antenna Module	V	V																		V																																				
D	2005	(DM)CTS	Body	Vehicle Theft Deterrent	V	V																																																					
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module	V	V			V				V			V	V				V	V		V	V						V																												
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module	V	V																		V										V	V																								
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V			V				V			V	V				V	V		V	V						V																												
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V																								
D	2005	(DP)CTS	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																		
D	2005	(DP)CTS	Chassis	VES	V	V																		V																																				
D	2005	(DP)CTS	Body	Amplifier (Bose)	V	V																																																					
D	2005	(DP)CTS	Body	Amplifier (Delco)	V	V																		V																																				
D	2005	(DP)CTS	Body	Climate Control Panel	V	V																		V																																				
D	2005	(DP)CTS	Body	Dash Integration Module	V	V																		V																																				
D	2005	(DP)CTS	Body	Digital Radio Receiver	V	V																			V																																			
D	2005	(DP)CTS	Body	Driver Door Switch	V	V																																																					
D	2005	(DP)CTS	Body	Driver Door Module	V	V																		V																																				
D	2005	(DP)CTS	Body	Passenger Door Module	V	V																		V																																				
D	2005	(DP)CTS	Body	Left Rear Door Module	V	V																		V																																				
D	2005	(DP)CTS	Body	Right Rear Door Module	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2005	(DP)CTS	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2005	(DP)CTS	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																		
D	2005	(DP)CTS	Body	Instrument Panel Cluster	V	V																		V																																			
D	2005	(DP)CTS	Body	Memory Seat Module	V	V																		V																																			
D	2005	(DP)CTS	Body	Personalization																																																							
D	2005	(DP)CTS	Body	Rear Integration Module	V	V																		V																																			
D	2005	(DP)CTS	Body	Remote Control Door Lock Receiver	V	V																																																					
D	2005	(DP)CTS	Body	Supplemental Inflatable Restraint	V	V																																																					
D	2005	(DP)CTS	Body	TV Antenna Module	V	V																		V																																			
D	2005	(DP)CTS	Body	Vehicle Theft Deterrent	V	V																																																					
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module	V	V			V				V			V	V				V	V		V	V							V																											
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module	V	V																		V											V	V																							
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V			V				V			V	V				V	V		V	V							V																											
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V											V	V																							
D	2005	(DR)CTS	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																		
D	2005	(DR)CTS	Chassis	VES	V	V																		V																																			
D	2005	(DR)CTS	Body	Amplifier (Bose)	V	V																																																					
D	2005	(DR)CTS	Body	Amplifier (Delco)	V	V																		V																																			
D	2005	(DR)CTS	Body	Climate Control Panel	V	V																		V																																			
D	2005	(DR)CTS	Body	Dash Integration Module	V	V																		V																																			
D	2005	(DR)CTS	Body	Digital Radio Receiver	V	V																			V																																		
D	2005	(DR)CTS	Body	Driver Door Switch	V	V																																																				
D	2005	(DR)CTS	Body	Driver Door Module	V	V																		V																																			
D	2005	(DR)CTS	Body	Passenger Door Module	V	V																		V																																			
D	2005	(DR)CTS	Body	Left Rear Door Module	V	V																		V																																			
D	2005	(DR)CTS	Body	Right Rear Door Module	V	V																		V																																			
D	2005	(DR)CTS	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																		
D	2005	(DR)CTS	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																		
D	2005	(DR)CTS	Body	Instrument Panel Cluster	V	V																		V																																			
D	2005	(DR)CTS	Body	Memory Seat Module	V	V																		V																																			
D	2005	(DR)CTS	Body	Personalization																																																						
D	2005	(DR)CTS	Body	Radio	V	V																																																				
D	2005	(DR)CTS	Body	Rear Integration Module	V	V																		V																																			
D	2005	(DR)CTS	Body	Remote Control Door Lock Receiver	V	V																																																				
D	2005	(DR)CTS	Body	Supplemental Inflatable Restraint	V	V																																																				
D	2005	(DR)CTS	Body	TV Antenna Module	V	V																		V																																			
D	2005	(DR)CTS	Body	Vehicle Theft Deterrent	V	V																																																				
D	2005	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
D	2005	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																		
D	2005	(DN)CTS-V	Chassis	Tire Pressure Monitor	V	V																		V																																			
D	2005	(DN)CTS-V	Chassis	VES	V	V																		V																																			
D	2005	(DN)CTS-V	Body	Amplifier (Bose)	V	V																																																				
D	2005	(DN)CTS-V	Body	Amplifier (Delco)	V	V																		V																																			
D	2005	(DN)CTS-V	Body	Climate Control Panel	V	V																		V																																			
D	2005	(DN)CTS-V	Body	Dash Integration Module	V	V																		V																																			
D	2005	(DN)CTS-V	Body	Digital Radio Receiver	V	V																			V																																		
D	2005	(DN)CTS-V	Body	Driver Door Switch	V	V																																																				
D	2005	(DN)CTS-V	Body	Driver Door Module	V	V																		V																																			
D	2005	(DN)CTS-V	Body	Passenger Door Module	V	V																		V																																			
D	2005	(DN)CTS-V	Body	Left Rear Door Module	V	V																		V																																			
D	2005	(DN)CTS-V	Body	Right Rear Door Module	V	V																		V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2005	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																				
D	2005	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																				
D	2005	(DN)CTS-V	Body	Instrument Panel Cluster	V	V																		V																																					
D	2005	(DN)CTS-V	Body	Memory Seat Module	V	V																		V																																					
D	2005	(DN)CTS-V	Body	Personalization																																																									
D	2005	(DN)CTS-V	Body	Radio	V	V																																																						
D	2005	(DN)CTS-V	Body	Rear Integration Module	V	V																		V																																					
D	2005	(DN)CTS-V	Body	Remote Control Door Lock Receiver	V	V																																																							
D	2005	(DN)CTS-V	Body	Supplemental Inflatable Restraint	V	V																																																							
D	2005	(DN)CTS-V	Body	TV Antenna Module	V	V																		V																																					
D	2005	(DN)CTS-V	Body	Vehicle Theft Deterrent	V	V																																																							
D	2005	(DC)STS-V8	Powertrain	Engine Control Module	V	V			V				V			V	V	V			V	V		V	V							V														V														
D	2005	(DC)STS-V8	Powertrain	Transmission Control Module	V	V																		V											V	V																								
D	2005	(DC)STS-V8	Chassis	Electronic Brake Control Module	V	V																			V																																				
D	2005	(DC)STS-V8	Chassis	Electronic Suspension Control	V	V																		V																																					
D	2005	(DC)STS-V8	Body	Amplifier (Bose)	V	V																		V																																					
D	2005	(DC)STS-V8	Body	Digital Radio Receiver	V	V																			V																																				
D	2005	(DC)STS-V8	Body	Distance Sensing Cruise Control	V	V																			V																																				
D	2005	(DC)STS-V8	Body	Driver Door Module	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Driver Door Switch	V	V																			V																																				
D	2005	(DC)STS-V8	Body	Driver Position Module	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Headlamp Control Module	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Head Up Display	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	HVAC Control Module	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Instrument Panel Cluster	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Instrument Panel Module	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Left Rear Door Module	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Passenger Door Module	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Uplevel Radio	V	V																			V																																				
D	2005	(DC)STS-V8	Body	Navigation Radio	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Rear Integration Module	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Right Rear Door Module	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Steering Column Lock Module	V	V																		V	V																																				
D	2005	(DC)STS-V8	Body	Supplemental Inflatable Restraint	V	V																			V																																				
D	2005	(DC)STS-V8	Body	TV Antenna Module	V	V																			V																																				
D	2005	(DC)STS-V8	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V			V				V			V	V				V	V		V	V							V																													
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V											V	V																								
D	2005	(DW)STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V											V	V																								
D	2005	(DW)STS	Chassis	Electronic Brake Control Module	V	V																			V																																				
D	2005	(DW)STS	Chassis	Electronic Suspension Control	V	V																		V																																					
D	2005	(DW)STS	Body	Amplifier (Bose)	V	V																		V																																					
D	2005	(DW)STS	Body	Digital Radio Receiver	V	V																			V																																				
D	2005	(DW)STS	Body	Distance Sensing Cruise Control	V	V																			V																																				
D	2005	(DW)STS	Body	Driver Door Module	V	V																		V	V																																				
D	2005	(DW)STS	Body	Driver Door Switch	V	V																			V																																				
D	2005	(DW)STS	Body	Driver Position Module	V	V																		V	V																																				
D	2005	(DW)STS	Body	Headlamp Control Module	V	V																		V	V																																				
D	2005	(DW)STS	Body	Head Up Display	V	V																		V	V																																				
D	2005	(DW)STS	Body	HVAC Control Module	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2005	(DW)STS	Body	Instrument Panel Cluster	V	V																		V	V																																				
D	2005	(DW)STS	Body	Instrument Panel Module	V	V																		V	V																																				
D	2005	(DW)STS	Body	Left Rear Door Module	V	V																		V	V																																				
D	2005	(DW)STS	Body	Passenger Door Module	V	V																		V	V																																				
D	2005	(DW)STS	Body	Uplevel Radio	V	V																			V																																				
D	2005	(DW)STS	Body	Navigation Radio	V	V																		V	V																																				
D	2005	(DW)STS	Body	Rear Integration Module	V	V																		V	V																																				
D	2005	(DW)STS	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
D	2005	(DW)STS	Body	Right Rear Door Module	V	V																		V	V																																				
D	2005	(DW)STS	Body	Steering Column Lock Module	V	V																		V	V																																				
D	2005	(DW)STS	Body	Supplemental Inflatable Restraint	V	V																			V																																				
D	2005	(DW)STS	Body	TV Antenna Module	V	V																			V																																				
D	2005	(DW)STS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V			V																									
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module	V	V																		V											V	V																								
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V			V																									
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V											V	V																								
D	2006	(DM)CTS	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																				
D	2006	(DM)CTS	Chassis	Tire Pressure Monitor	V	V																		V																																				
D	2006	(DM)CTS	Chassis	VES	V	V																		V																																				
D	2006	(DM)CTS	Body	Amplifier (Bose)	V	V																																																						
D	2006	(DM)CTS	Body	Amplifier (Delco)	V	V																		V																																				
D	2006	(DM)CTS	Body	Climate Control Panel	V	V																		V																																				
D	2006	(DM)CTS	Body	Dash Integration Module	V	V																		V																																				
D	2006	(DM)CTS	Body	Digital Radio Receiver	V	V																			V																																			
D	2006	(DM)CTS	Body	Driver Door Switch	V	V																																																					
D	2006	(DM)CTS	Body	Driver Door Module	V	V																		V																																				
D	2006	(DM)CTS	Body	Passenger Door Module	V	V																		V																																				
D	2006	(DM)CTS	Body	Left Rear Door Module	V	V																		V																																				
D	2006	(DM)CTS	Body	Right Rear Door Module	V	V																		V																																				
D	2006	(DM)CTS	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2006	(DM)CTS	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2006	(DM)CTS	Body	Instrument Panel Cluster	V	V																		V																																				
D	2006	(DM)CTS	Body	Memory Seat Module	V	V																		V																																				
D	2006	(DM)CTS	Body	Personalization																																																							
D	2006	(DM)CTS	Body	Radio	V	V																																																					
D	2006	(DM)CTS	Body	Rear Integration Module	V	V																		V																																				
D	2006	(DM)CTS	Body	Remote Control Door Lock Receiver	V	V																																																					
D	2006	(DM)CTS	Body	Supplemental Inflatable Restraint	V	V																																																					
D	2006	(DM)CTS	Body	TV Antenna Module	V	V																		V																																				
D	2006	(DM)CTS	Body	Vehicle Theft Deterrent	V	V																																																					
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V			V																									
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module	V	V																		V											V	V																								
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V			V																									
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V											V	V																								
D	2006	(DP)CTS	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																				
D	2006	(DP)CTS	Chassis	Tire Pressure Monitor	V	V																		V																																				
D	2006	(DP)CTS	Chassis	VES	V	V																		V																																				
D	2006	(DP)CTS	Body	Amplifier (Bose)	V	V																																																					
D	2006	(DP)CTS	Body	Amplifier (Delco)	V	V																		V																																				
D	2006	(DP)CTS	Body	Climate Control Panel	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2006	(DP)CTS	Body	Dash Integration Module	V	V																		V																																				
D	2006	(DP)CTS	Body	Digital Radio Receiver	V	V																			V																																			
D	2006	(DP)CTS	Body	Driver Door Switch	V	V																																																					
D	2006	(DP)CTS	Body	Driver Door Module	V	V																		V																																			
D	2006	(DP)CTS	Body	Passenger Door Module	V	V																		V																																			
D	2006	(DP)CTS	Body	Left Rear Door Module	V	V																		V																																			
D	2006	(DP)CTS	Body	Right Rear Door Module	V	V																		V																																			
D	2006	(DP)CTS	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																		
D	2006	(DP)CTS	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																		
D	2006	(DP)CTS	Body	Instrument Panel Cluster	V	V																		V																																			
D	2006	(DP)CTS	Body	Memory Seat Module	V	V																		V																																			
D	2006	(DP)CTS	Body	Personalization																																																							
D	2006	(DP)CTS	Body	Radio	V	V																																																					
D	2006	(DP)CTS	Body	Rear Integration Module	V	V																		V																																			
D	2006	(DP)CTS	Body	Remote Control Door Lock Receiver	V	V																																																					
D	2006	(DP)CTS	Body	Supplemental Inflatable Restraint	V	V																																																					
D	2006	(DP)CTS	Body	TV Antenna Module	V	V																		V																																			
D	2006	(DP)CTS	Body	Vehicle Theft Deterrent	V	V																																																					
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V			V																								
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module	V	V																		V											V	V																							
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V			V																								
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V											V	V																							
D	2006	(DR)CTS	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																		
D	2006	(DR)CTS	Chassis	Tire Pressure Monitor	V	V																		V																																			
D	2006	(DR)CTS	Chassis	VES	V	V																		V																																			
D	2006	(DR)CTS	Body	Amplifier (Bose)	V	V																																																					
D	2006	(DR)CTS	Body	Amplifier (Delco)	V	V																		V																																			
D	2006	(DR)CTS	Body	Climate Control Panel	V	V																		V																																			
D	2006	(DR)CTS	Body	Dash Integration Module	V	V																		V																																			
D	2006	(DR)CTS	Body	Digital Radio Receiver	V	V																			V																																			
D	2006	(DR)CTS	Body	Driver Door Switch	V	V																																																					
D	2006	(DR)CTS	Body	Driver Door Module	V	V																		V																																			
D	2006	(DR)CTS	Body	Passenger Door Module	V	V																		V																																			
D	2006	(DR)CTS	Body	Left Rear Door Module	V	V																		V																																			
D	2006	(DR)CTS	Body	Right Rear Door Module	V	V																		V																																			
D	2006	(DR)CTS	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																		
D	2006	(DR)CTS	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																		
D	2006	(DR)CTS	Body	Instrument Panel Cluster	V	V																		V																																			
D	2006	(DR)CTS	Body	Memory Seat Module	V	V																		V																																			
D	2006	(DR)CTS	Body	Personalization																																																						
D	2006	(DR)CTS	Body	Radio	V	V																																																				
D	2006	(DR)CTS	Body	Rear Integration Module	V	V																		V																																			
D	2006	(DR)CTS	Body	Remote Control Door Lock Receiver	V	V																																																					
D	2006	(DR)CTS	Body	Supplemental Inflatable Restraint	V	V																																																					
D	2006	(DR)CTS	Body	TV Antenna Module	V	V																		V																																			
D	2006	(DR)CTS	Body	Vehicle Theft Deterrent	V	V																																																					
D	2006	(DN)CTS-V	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V												
D	2006	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																		
D	2006	(DN)CTS-V	Chassis	Tire Pressure Monitor	V	V																		V																																			
D	2006	(DN)CTS-V	Chassis	VES	V	V																		V																																			
D	2006	(DN)CTS-V	Body	Amplifier (Bose)	V	V																																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2006	(DN)CTS-V	Body	Amplifier (Delco)	V	V																		V																																				
D	2006	(DN)CTS-V	Body	Climate Control Panel	V	V																		V																																			
D	2006	(DN)CTS-V	Body	Dash Integration Module	V	V																		V																																			
D	2006	(DN)CTS-V	Body	Digital Radio Receiver	V	V																			V																																		
D	2006	(DN)CTS-V	Body	Driver Door Switch	V	V																																																					
D	2006	(DN)CTS-V	Body	Driver Door Module	V	V																		V																																			
D	2006	(DN)CTS-V	Body	Passenger Door Module	V	V																		V																																			
D	2006	(DN)CTS-V	Body	Left Rear Door Module	V	V																		V																																			
D	2006	(DN)CTS-V	Body	Right Rear Door Module	V	V																		V																																			
D	2006	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																		
D	2006	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																		
D	2006	(DN)CTS-V	Body	Instrument Panel Cluster	V	V																		V																																			
D	2006	(DN)CTS-V	Body	Memory Seat Module	V	V																		V																																			
D	2006	(DN)CTS-V	Body	Personalization																																																						
D	2006	(DN)CTS-V	Body	Rear Integration Module	V	V																		V																																			
D	2006	(DN)CTS-V	Body	Remote Control Door Lock Receiver	V	V																																																				
D	2006	(DN)CTS-V	Body	Supplemental Inflatable Restraint	V	V																																																				
D	2006	(DN)CTS-V	Body	TV Antenna Module	V	V																		V																																			
D	2006	(DN)CTS-V	Body	Vehicle Theft Deterrent	V	V																																																				
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Engine Controls	V	V			V				V			V	V	V			V	V		V	V							V														V												
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V										V	V																							
D	2006	(DC)STS-V8	Chassis	Electronic Brake Control Module	V	V																			V																																		
D	2006	(DC)STS-V8	Chassis	Electronic Suspension Control	V	V																		V																																			
D	2006	(DC)STS-V8	Body	Amplifier (Bose)	V	V																		V																																			
D	2006	(DC)STS-V8	Body	Digital Radio Receiver	V	V																			V																																		
D	2006	(DC)STS-V8	Body	Distance Sensing Cruise Control	V	V																			V																																		
D	2006	(DC)STS-V8	Body	Driver Door Module	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Driver Door Switch	V	V																			V																																		
D	2006	(DC)STS-V8	Body	Driver Position Module	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Headlamp Control Module	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Head Up Display	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	HVAC Control Module	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Instrument Panel Cluster	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Instrument Panel Module	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Left Rear Door Module	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Passenger Door Module	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Uplevel Radio	V	V																			V																																		
D	2006	(DC)STS-V8	Body	Navigation Radio	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Rear Integration Module	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Right Rear Door Module	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Steering Column Lock Module	V	V																		V	V																																		
D	2006	(DC)STS-V8	Body	Supplemental Inflatable Restraint	V	V																			V																																		
D	2006	(DC)STS-V8	Body	TV Antenna Module	V	V																			V																																		
D	2006	(DC)STS-V8	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V			V																							
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V																							
D	2006	(DW)STS	Chassis	Electronic Brake Control Module	V	V																			V																																		
D	2006	(DW)STS	Chassis	Electronic Suspension Control	V	V																		V																																			
D	2006	(DW)STS	Body	Amplifier (Bose)	V	V																		V																																			
D	2006	(DW)STS	Body	Digital Radio Receiver	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2006	(DW)STS	Body	Distance Sensing Cruise Control	V	V																			V																																			
D	2006	(DW)STS	Body	Driver Door Module	V	V																		V	V																																		
D	2006	(DW)STS	Body	Driver Door Switch	V	V																			V																																		
D	2006	(DW)STS	Body	Driver Position Module	V	V																		V	V																																		
D	2006	(DW)STS	Body	Headlamp Control Module	V	V																		V	V																																		
D	2006	(DW)STS	Body	Head Up Display	V	V																		V	V																																		
D	2006	(DW)STS	Body	HVAC Control Module	V	V																		V	V																																		
D	2006	(DW)STS	Body	Instrument Panel Cluster	V	V																		V	V																																		
D	2006	(DW)STS	Body	Instrument Panel Module	V	V																		V	V																																		
D	2006	(DW)STS	Body	Left Rear Door Module	V	V																		V	V																																		
D	2006	(DW)STS	Body	Passenger Door Module	V	V																		V	V																																		
D	2006	(DW)STS	Body	Uplevel Radio	V	V																			V																																		
D	2006	(DW)STS	Body	Navigation Radio	V	V																		V	V																																		
D	2006	(DW)STS	Body	Rear Integration Module	V	V																		V	V																																		
D	2006	(DW)STS	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
D	2006	(DW)STS	Body	Right Rear Door Module	V	V																		V	V																																		
D	2006	(DW)STS	Body	Steering Column Lock Module	V	V																		V	V																																		
D	2006	(DW)STS	Body	Supplemental Inflatable Restraint	V	V																			V																																		
D	2006	(DW)STS	Body	TV Antenna Module	V	V																			V																																		
D	2006	(DW)STS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V		V													
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Transmission Control Module	V	V																		V										V	V	V																						
D	2006	(DX)STS-V	Chassis	Electronic Brake Control Module	V	V																			V																																		
D	2006	(DX)STS-V	Chassis	Electronic Suspension Control	V	V																		V																																		
D	2006	(DX)STS-V	Body	Amplifier (Bose)	V	V																		V																																		
D	2006	(DX)STS-V	Body	Digital Radio Receiver	V	V																			V																																		
D	2006	(DX)STS-V	Body	Distance Sensing Cruise Control	V	V																			V																																		
D	2006	(DX)STS-V	Body	Driver Door Module	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Driver Door Switch	V	V																			V																																		
D	2006	(DX)STS-V	Body	Driver Position Module	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Headlamp Control Module	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Head Up Display	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	HVAC Control Module	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Instrument Panel Cluster	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Instrument Panel Module	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Left Rear Door Module	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Passenger Door Module	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Uplevel Radio	V	V																			V																																		
D	2006	(DX)STS-V	Body	Navigation Radio	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Rear Integration Module	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Right Rear Door Module	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Steering Column Lock Module	V	V																		V	V																																		
D	2006	(DX)STS-V	Body	Supplemental Inflatable Restraint	V	V																			V																																		
D	2006	(DX)STS-V	Body	TV Antenna Module	V	V																			V																																		
D	2006	(DX)STS-V	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module	V	V																		V										V	V																						
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V																									
D	2007	(DM)CTS	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																		
D	2007	(DM)CTS	Chassis	VES	V	V																		V																																				
D	2007	(DM)CTS	Body	Amplifier (Bose)	V	V																																																						
D	2007	(DM)CTS	Body	Amplifier (Delco)	V	V																		V																																				
D	2007	(DM)CTS	Body	Climate Control Panel	V	V																		V																																				
D	2007	(DM)CTS	Body	Dash Integration Module	V	V																		V																																				
D	2007	(DM)CTS	Body	Digital Radio Receiver	V	V																			V																																			
D	2007	(DM)CTS	Body	Driver Door Switch	V	V																																																						
D	2007	(DM)CTS	Body	Driver Door Module	V	V																		V																																				
D	2007	(DM)CTS	Body	Passenger Door Module	V	V																		V																																				
D	2007	(DM)CTS	Body	Left Rear Door Module	V	V																		V																																				
D	2007	(DM)CTS	Body	Right Rear Door Module	V	V																		V																																				
D	2007	(DM)CTS	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2007	(DM)CTS	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2007	(DM)CTS	Body	Instrument Panel Cluster	V	V																		V																																				
D	2007	(DM)CTS	Body	Memory Seat Module	V	V																		V																																				
D	2007	(DM)CTS	Body	Personalization																																																							
D	2007	(DM)CTS	Body	Rear Integration Module	V	V																		V																																				
D	2007	(DM)CTS	Body	Remote Control Door Lock Receiver	V	V																		V																																				
D	2007	(DM)CTS	Body	Supplemental Inflatable Restraint	V	V																																																					
D	2007	(DM)CTS	Body	Theft Deterrent Module	V	V																																																					
D	2007	(DM)CTS	Body	TV Antenna Module	V	V																		V																																				
D	2007	(DM)CTS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module	V	V																		V										V	V																								
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V																								
D	2007	(DP)CTS	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																		
D	2007	(DP)CTS	Chassis	VES	V	V																		V																																				
D	2007	(DP)CTS	Body	Amplifier (Bose)	V	V																																																					
D	2007	(DP)CTS	Body	Amplifier (Delco)	V	V																		V																																				
D	2007	(DP)CTS	Body	Climate Control Panel	V	V																		V																																				
D	2007	(DP)CTS	Body	Dash Integration Module	V	V																		V																																				
D	2007	(DP)CTS	Body	Digital Radio Receiver	V	V																			V																																			
D	2007	(DP)CTS	Body	Driver Door Switch	V	V																																																					
D	2007	(DP)CTS	Body	Driver Door Module	V	V																		V																																				
D	2007	(DP)CTS	Body	Passenger Door Module	V	V																		V																																				
D	2007	(DP)CTS	Body	Left Rear Door Module	V	V																		V																																				
D	2007	(DP)CTS	Body	Right Rear Door Module	V	V																		V																																				
D	2007	(DP)CTS	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2007	(DP)CTS	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2007	(DP)CTS	Body	Instrument Panel Cluster	V	V																		V																																				
D	2007	(DP)CTS	Body	Memory Seat Module	V	V																		V																																				
D	2007	(DP)CTS	Body	Personalization																																																						
D	2007	(DP)CTS	Body	Rear Integration Module	V	V																		V																																				
D	2007	(DP)CTS	Body	Remote Control Door Lock Receiver	V	V																		V																																				
D	2007	(DP)CTS	Body	Supplemental Inflatable Restraint	V	V																																																					
D	2007	(DP)CTS	Body	Theft Deterrent Module	V	V																																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2007	(DP)CTS	Body	TV Antenna Module	V	V																		V																																						
D	2007	(DP)CTS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																	
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																	
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module	V	V																		V										V	V																									
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																	
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																	
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V																									
D	2007	(DR)CTS	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																			
D	2007	(DR)CTS	Chassis	VES	V	V																		V																																				
D	2007	(DR)CTS	Body	Amplifier (Bose)	V	V																																																						
D	2007	(DR)CTS	Body	Amplifier (Delco)	V	V																		V																																				
D	2007	(DR)CTS	Body	Climate Control Panel	V	V																		V																																				
D	2007	(DR)CTS	Body	Dash Integration Module	V	V																		V																																				
D	2007	(DR)CTS	Body	Digital Radio Receiver	V	V																			V																																			
D	2007	(DR)CTS	Body	Driver Door Switch	V	V																																																					
D	2007	(DR)CTS	Body	Driver Door Module	V	V																		V																																				
D	2007	(DR)CTS	Body	Passenger Door Module	V	V																		V																																				
D	2007	(DR)CTS	Body	Left Rear Door Module	V	V																		V																																				
D	2007	(DR)CTS	Body	Right Rear Door Module	V	V																		V																																				
D	2007	(DR)CTS	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2007	(DR)CTS	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2007	(DR)CTS	Body	Instrument Panel Cluster	V	V																		V																																				
D	2007	(DR)CTS	Body	Memory Seat Module	V	V																		V																																				
D	2007	(DR)CTS	Body	Personalization																																																							
D	2007	(DR)CTS	Body	Rear Integration Module	V	V																		V																																				
D	2007	(DR)CTS	Body	Remote Control Door Lock Receiver	V	V																		V																																				
D	2007	(DR)CTS	Body	Supplemental Inflatable Restraint	V	V																																																					
D	2007	(DR)CTS	Body	Theft Deterrent Module	V	V																																																					
D	2007	(DR)CTS	Body	TV Antenna Module	V	V																		V																																				
D	2007	(DR)CTS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
D	2007	(DN)CTS-V	Powertrain	(U)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V															
D	2007	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																			
D	2007	(DN)CTS-V	Chassis	VES	V	V																		V																																				
D	2007	(DN)CTS-V	Body	Amplifier (Bose)	V	V																																																					
D	2007	(DN)CTS-V	Body	Amplifier (Delco)	V	V																		V																																				
D	2007	(DN)CTS-V	Body	Climate Control Panel	V	V																		V																																				
D	2007	(DN)CTS-V	Body	Dash Integration Module	V	V																		V																																				
D	2007	(DN)CTS-V	Body	Digital Radio Receiver	V	V																			V																																			
D	2007	(DN)CTS-V	Body	Driver Door Switch	V	V																																																					
D	2007	(DN)CTS-V	Body	Driver Door Module	V	V																		V																																				
D	2007	(DN)CTS-V	Body	Passenger Door Module	V	V																		V																																				
D	2007	(DN)CTS-V	Body	Left Rear Door Module	V	V																		V																																				
D	2007	(DN)CTS-V	Body	Right Rear Door Module	V	V																		V																																				
D	2007	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2007	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																			
D	2007	(DN)CTS-V	Body	Instrument Panel Cluster	V	V																		V																																				
D	2007	(DN)CTS-V	Body	Memory Seat Module	V	V																		V																																				
D	2007	(DN)CTS-V	Body	Personalization																																																							
D	2007	(DN)CTS-V	Body	Rear Integration Module	V	V																		V																																				
D	2007	(DN)CTS-V	Body	Remote Control Door Lock Receiver	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2007	(DN)CTS-V	Body	Supplemental Inflatable Restraint	V	V																																																						
D	2007	(DN)CTS-V	Body	Theft Deterrent Module	V	V																																																						
D	2007	(DN)CTS-V	Body	TV Antenna Module	V	V																		V																																				
D	2007	(DN)CTS-V	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
D	2007	(DC)STS-V8	Powertrain	Engine Control Module	V	V	V		V				V				V	V	V		V	V		V	V							V								V	V	V	V		V													
D	2007	(DC)STS-V8	Powertrain	Transmission Control Module	V	V																		V											V	V	V																						
D	2007	(DC)STS-V8	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
D	2007	(DC)STS-V8	Chassis	Electronic Suspension Control	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Amplifier (Bose)	V	V																		V																																			
D	2007	(DC)STS-V8	Body	Digital Radio Receiver	V	V																			V																																		
D	2007	(DC)STS-V8	Body	Distance Sensing Cruise Control	V	V																			V																																		
D	2007	(DC)STS-V8	Body	Driver Door Module	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Driver Door Switch	V	V																			V																																		
D	2007	(DC)STS-V8	Body	Driver Position Module	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Headlamp Control Module	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Head Up Display	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	HVAC Control Module	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Instrument Panel Cluster	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Instrument Panel Module	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Left Rear Door Module	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Passenger Door Module	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Uplevel Radio	V	V																			V																																		
D	2007	(DC)STS-V8	Body	Navigation Radio	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Rear Integration Module	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Right Rear Door Module	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Steering Column Lock Module	V	V																		V	V																																		
D	2007	(DC)STS-V8	Body	Supplemental Inflatable Restraint	V	V																			V																																		
D	2007	(DC)STS-V8	Body	TV Antenna Module	V	V																			V																																		
D	2007	(DC)STS-V8	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V											V	V																						
D	2007	(DW)STS	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
D	2007	(DW)STS	Chassis	Electronic Suspension Control	V	V																		V	V																																		
D	2007	(DW)STS	Body	Amplifier (Bose)	V	V																		V																																			
D	2007	(DW)STS	Body	Digital Radio Receiver	V	V																			V																																		
D	2007	(DW)STS	Body	Distance Sensing Cruise Control	V	V																			V																																		
D	2007	(DW)STS	Body	Driver Door Module	V	V																		V	V																																		
D	2007	(DW)STS	Body	Driver Door Switch	V	V																			V																																		
D	2007	(DW)STS	Body	Driver Position Module	V	V																		V	V																																		
D	2007	(DW)STS	Body	Headlamp Control Module	V	V																		V	V																																		
D	2007	(DW)STS	Body	Head Up Display	V	V																		V	V																																		
D	2007	(DW)STS	Body	HVAC Control Module	V	V																		V	V																																		
D	2007	(DW)STS	Body	Instrument Panel Cluster	V	V																		V	V																																		
D	2007	(DW)STS	Body	Instrument Panel Module	V	V																		V	V																																		
D	2007	(DW)STS	Body	Left Rear Door Module	V	V																		V	V																																		
D	2007	(DW)STS	Body	Passenger Door Module	V	V																		V	V																																		
D	2007	(DW)STS	Body	Uplevel Radio	V	V																			V																																		
D	2007	(DW)STS	Body	Navigation Radio	V	V																		V	V																																		
D	2007	(DW)STS	Body	Rear Integration Module	V	V																		V	V																																		
D	2007	(DW)STS	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2007	(DW)STS	Body	Right Rear Door Module	V	V																		V	V																																			
D	2007	(DW)STS	Body	Steering Column Lock Module	V	V																		V	V																																			
D	2007	(DW)STS	Body	Supplemental Inflatable Restraint	V	V																			V																																			
D	2007	(DW)STS	Body	TV Antenna Module	V	V																			V																																			
D	2007	(DW)STS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
D	2007	(DX)STS-V	Powertrain	Engine Control Module	V	V	V		V				V				V	V	V		V	V		V	V							V									V	V	V	V		V													
D	2007	(DX)STS-V	Powertrain	Transmission Control Module	V	V																		V										V	V	V																							
D	2007	(DX)STS-V	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
D	2007	(DX)STS-V	Chassis	Electronic Suspension Control	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Amplifier (Bose)	V	V																		V																																				
D	2007	(DX)STS-V	Body	Digital Radio Receiver	V	V																			V																																			
D	2007	(DX)STS-V	Body	Distance Sensing Cruise Control	V	V																			V																																			
D	2007	(DX)STS-V	Body	Driver Door Module	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Driver Door Switch	V	V																			V																																			
D	2007	(DX)STS-V	Body	Driver Position Module	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Headlamp Control Module	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Head Up Display	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	HVAC Control Module	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Instrument Panel Cluster	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Instrument Panel Module	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Left Rear Door Module	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Passenger Door Module	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Uplevel Radio	V	V																			V																																			
D	2007	(DX)STS-V	Body	Navigation Radio	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Rear Integration Module	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Right Rear Door Module	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Steering Column Lock Module	V	V																		V	V																																			
D	2007	(DX)STS-V	Body	Supplemental Inflatable Restraint	V	V																			V																																			
D	2007	(DX)STS-V	Body	TV Antenna Module	V	V																			V																																			
D	2007	(DX)STS-V	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V									V	V	V	V															
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module	V	V																		V										V	V	V																							
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V									V	V	V	V															
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module	V	V																		V										V	V	V																							
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module	V	V																		V	V																																			
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V									V	V	V	V															
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V	V																							
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module	V	V																		V	V																																			
D	2008	CTS	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
D	2008	CTS	Body	Body Control Module	V	V																		V	V																																			
D	2008	CTS	Body	Body Control Module (aux.)	V	V																		V	V																																			
D	2008	CTS	Body	Driver Door Switch	V	V																		V	V																																			
D	2008	CTS	Body	Headlamp Control Module	V	V																		V	V																																			
D	2008	CTS	Body	HVAC Control Module	V	V																		V	V																																			
D	2008	CTS	Body	Infotainment Faceplate Module																					V																																			
D	2008	CTS	Body	Instrument Panel Cluster	V	V																		V	V																																			
D	2008	CTS	Body	Memory Seat Module	V	V																		V	V																																			
D	2008	CTS	Body	Park Assist Module	V	V																		V	V																																			
D	2008	CTS	Body	Passenger Door Switch	V	V																		V	V																																			
D	2008	CTS	Body	Passenger Presence System	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2008	CTS	Body	Pedestrian Impact Detection Module	V	V																			V																																			
D	2008	CTS	Body	Radio	V	V																		V	V																																		
D	2008	CTS	Body	Supplemental Inflatable Restraint	V	V																			V																																		
D	2008	CTS	Body	TV Antenna Module	V	V																			V																																		
D	2008	CTS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V																										
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module	V	V																		V											V	V																						
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V																										
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V											V	V																						
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V	V		V				V				V	V	V		V	V		V	V							V								V	V	V	V		V													
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V											V	V	V																						
D	2008	SLS	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
D	2008	SLS	Chassis	Electronic Suspension Control	V	V																		V	V																																		
D	2008	SLS	Body	Amplifier (Bose)	V	V																		V																																		
D	2008	SLS	Body	Driver Door Module	V	V																		V	V																																		
D	2008	SLS	Body	Driver Door Switch	V	V																			V																																		
D	2008	SLS	Body	Driver Position Module	V	V																		V	V																																		
D	2008	SLS	Body	Headlamp Control Module	V	V																			V																																		
D	2008	SLS	Body	HVAC Control Module	V	V																		V	V																																		
D	2008	SLS	Body	Instrument Panel Cluster	V	V																		V	V																																		
D	2008	SLS	Body	Instrument Panel Module	V	V																		V	V																																		
D	2008	SLS	Body	Left Rear Door Module	V	V																		V	V																																		
D	2008	SLS	Body	Passenger Door Module	V	V																		V	V																																		
D	2008	SLS	Body	Radio	V	V																		V	V																																		
D	2008	SLS	Body	Rear HVAC/RSA	V	V																		V	V																																		
D	2008	SLS	Body	Rear Integration Module	V	V																		V	V																																		
D	2008	SLS	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
D	2008	SLS	Body	Right Rear Door Module	V	V																		V	V																																		
D	2008	SLS	Body	Supplemental Inflatable Restraint	V	V																			V																																		
D	2008	SLS	Body	TV Antenna Module	V	V																			V																																		
D	2008	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V															
D	2008	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module	V	V																		V											V	V	V																						
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V		V													
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module	V	V																		V											V	V	V																						
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V		V													
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V											V	V	V																						
D	2008	STS	Chassis	Electronic Brake Control Module With (RPO JL7)	V	V																		V	V																																		
D	2008	STS	Chassis	Electronic Suspension Control With (RPO JL7)	V	V																		V	V																																		
D	2008	STS	Chassis	Power Steering Control Module With (RPO JL7)	V	V																																																				
D	2008	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)	V	V																																																				
D	2008	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)	V	V																		V	V																																		
D	2008	STS	Chassis	Electronic Suspension Control Without (RPO JL7)	V	V																		V	V																																		
D	2008	STS	Body	Amplifier (Bose)	V	V																		V																																		
D	2008	STS	Body	Digital Radio Receiver	V	V																			V																																		
D	2008	STS	Body	Distance Sensing Cruise Control	V	V																			V																																		
D	2008	STS	Body	Driver Door Module	V	V																		V	V																																		
D	2008	STS	Body	Driver Door Switch	V	V																			V																																		
D	2008	STS	Body	Driver Position Module	V	V																		V	V																																		
D	2008	STS	Body	Headlamp Control Module	V	V																		V	V																																		
D	2008	STS	Body	Head Up Display	V	V																		V	V																																		
D	2008	STS	Body	HVAC Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2008	STS	Body	Instrument Panel Cluster	V	V																		V	V																																				
D	2008	STS	Body	Instrument Panel Module	V	V																		V	V																																				
D	2008	STS	Body	Left Rear Door Module	V	V																		V	V																																				
D	2008	STS	Body	Left Side Object Detection Module	V	V																		V	V																																				
D	2008	STS	Body	Passenger Door Module	V	V																		V	V																																				
D	2008	STS	Body	Uplevel Radio	V	V																			V																																				
D	2008	STS	Body	Navigation Radio	V	V																		V	V																																				
D	2008	STS	Body	Rear Integration Module	V	V																		V	V																																				
D	2008	STS	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
D	2008	STS	Body	Right Rear Door Module	V	V																		V	V																																				
D	2008	STS	Body	Right Side Object Detection Module	V	V																			V																																				
D	2008	STS	Body	Steering Column Lock Module	V	V																		V	V																																				
D	2008	STS	Body	Supplemental Inflatable Restraint	V	V																			V																																				
D	2008	STS	Body	TV Antenna Module	V	V																			V																																				
D	2008	STS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
D	2008	STS	Body	Veh Direction Alert Alarm Warn Mod	V	V																			V																																				
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module	V	V																		V	V																																			
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module	V	V																		V										V	V	V																							
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V								V	V	V	V															
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module	V	V																		V										V	V	V																							
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V															
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module	V	V																		V										V	V	V																							
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module	V	V																		V	V																																			
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V								V	V	V	V															
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V	V																							
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module	V	V																		V	V																																			
D	2009	CTS	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
D	2009	CTS	Chassis	Electronic Suspension Control	V	V																		V																																				
D	2009	CTS	Chassis	Parking Brake Control Module	V	V																		V	V																																			
D	2009	CTS	Body	Body Control Module	V	V																		V	V																																			
D	2009	CTS	Body	Body Control Module (aux.)	V	V																		V	V																																			
D	2009	CTS	Body	Driver Door Switch	V	V																		V	V																																			
D	2009	CTS	Body	Headlamp Control Module	V	V																		V	V																																			
D	2009	CTS	Body	HVAC Control Module	V	V																		V	V																																			
D	2009	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)	V	V																		V	V																																			
D	2009	CTS	Body	Instrument Panel Cluster (Other)	V	V																		V	V																																			
D	2009	CTS	Body	Memory Seat Module	V	V																		V	V																																			
D	2009	CTS	Body	Park Assist Module	V	V																		V	V																																			
D	2009	CTS	Body	Passenger Door Switch	V	V																		V	V																																			
D	2009	CTS	Body	Passenger Presence System	V	V																			V																																			
D	2009	CTS	Body	Pedestrian Impact Detection Module	V	V																			V																																			
D	2009	CTS	Body	Radio	V	V																		V	V																																			
D	2009	CTS	Body	Supplemental Inflatable Restraint	V	V																			V																																			
D	2009	CTS	Body	TV Antenna Module	V	V																			V																																			
D	2009	CTS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
D	2009	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V																												
D	2009	SLS	Powertrain	(T)2.8L V6 LP2 Transmission Control Module	V	V																		V										V	V																							
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V																												
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V	V		V				V				V	V	V		V	V		V	V							V								V	V	V	V		V														
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V										V	V	V																								
D	2009	SLS	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
D	2009	SLS	Chassis	Electronic Suspension Control	V	V																		V	V																																			
D	2009	SLS	Body	Amplifier (Bose)	V	V																		V																																				
D	2009	SLS	Body	Driver Door Module	V	V																		V	V																																			
D	2009	SLS	Body	Driver Door Switch	V	V																			V																																			
D	2009	SLS	Body	Driver Position Module	V	V																		V	V																																			
D	2009	SLS	Body	Headlamp Control Module	V	V																			V																																			
D	2009	SLS	Body	HVAC Control Module	V	V																		V	V																																			
D	2009	SLS	Body	Instrument Panel Cluster	V	V																		V	V																																			
D	2009	SLS	Body	Instrument Panel Module	V	V																		V	V																																			
D	2009	SLS	Body	Left Rear Door Module	V	V																		V	V																																			
D	2009	SLS	Body	Passenger Door Module	V	V																		V	V																																			
D	2009	SLS	Body	Radio	V	V																		V	V																																			
D	2009	SLS	Body	Rear HVAC/RSA	V	V																		V	V																																			
D	2009	SLS	Body	Rear Integration Module	V	V																		V	V																																			
D	2009	SLS	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
D	2009	SLS	Body	Right Rear Door Module	V	V																		V	V																																			
D	2009	SLS	Body	Supplemental Inflatable Restraint	V	V																			V																																			
D	2009	SLS	Body	TV Antenna Module	V	V																			V																																			
D	2009	SLS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
D	2009	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V																
D	2009	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module	V	V																		V										V	V	V																								
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V		V														
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module	V	V																		V										V	V	V																								
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V		V														
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V										V	V	V																								
D	2009	STS	Chassis	Electronic Brake Control Module With (RPO JL7)	V	V																		V	V																																			
D	2009	STS	Chassis	Electronic Suspension Control With (RPO JL7)	V	V																		V	V																																			
D	2009	STS	Chassis	Power Steering Control Module With (RPO JL7)	V	V																																																					
D	2009	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)	V	V																																																					
D	2009	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)	V	V																		V	V																																			
D	2009	STS	Chassis	Electronic Suspension Control Without (RPO JL7)	V	V																		V	V																																			
D	2009	STS	Body	Amplifier (Bose)	V	V																		V																																				
D	2009	STS	Body	Digital Radio Receiver	V	V																		V																																				
D	2009	STS	Body	Distance Sensing Cruise Control	V	V																			V																																			
D	2009	STS	Body	Driver Door Module	V	V																		V	V																																			
D	2009	STS	Body	Driver Door Switch	V	V																			V																																			
D	2009	STS	Body	Driver Position Module	V	V																		V	V																																			
D	2009	STS	Body	Headlamp Control Module	V	V																		V	V																																			
D	2009	STS	Body	Head Up Display	V	V																		V	V																																			
D	2009	STS	Body	HVAC Control Module	V	V																		V	V																																			
D	2009	STS	Body	Instrument Panel Cluster	V	V																		V	V																																			
D	2009	STS	Body	Instrument Panel Module	V	V																		V	V																																			
D	2009	STS	Body	Left Rear Door Module	V	V																		V	V																																			
D	2009	STS	Body	Left Side Object Detection Module	V	V																		V	V																																			
D	2009	STS	Body	Passenger Door Module	V	V																		V	V																																			
D	2009	STS	Body	Uplevel Radio	V	V																			V																																			
D	2009	STS	Body	Navigation Radio	V	V																		V	V																																			
D	2009	STS	Body	Rear Integration Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2009	STS	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
D	2009	STS	Body	Right Rear Door Module	V	V																		V	V																																				
D	2009	STS	Body	Right Side Object Detection Module	V	V																			V																																				
D	2009	STS	Body	Steering Column Lock Module	V	V																		V	V																																				
D	2009	STS	Body	Supplemental Inflatable Restraint	V	V																			V																																				
D	2009	STS	Body	TV Antenna Module	V	V																			V																																				
D	2009	STS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
D	2009	STS	Body	Veh Direction Alert Alarm Warn Mod	V	V																			V																																				
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module	V	V																		V	V																																			
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module	V	V																		V										V	V	V																								
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Auto	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V														
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Manual	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V	V	V														
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transmission Control Module	V	V																		V										V	V	V																								
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Fuel Pump Control Module	V	V																		V	V																																			
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transfer Case Control Module	V	V																		V	V																																			
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module Auto	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V																
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module	V	V																		V										V	V	V																								
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Fuel Pump Control Module	V	V																		V	V																																			
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module	V	V																		V	V																																			
D	2010	CTS	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
D	2010	CTS	Chassis	Electronic Suspension Control	V	V																		V																																					
D	2010	CTS	Chassis	Parking Brake Control Module	V	V																		V	V																																				
D	2010	CTS	Body	Body Control Module	V	V																		V	V																																				
D	2010	CTS	Body	Body Control Module (aux.)	V	V																		V	V																																				
D	2010	CTS	Body	Driver Door Switch	V	V																		V	V																																				
D	2010	CTS	Body	Headlamp Control Module	V	V																		V	V																																				
D	2010	CTS	Body	HVAC Control Module	V	V																		V	V																																				
D	2010	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)	V	V																		V	V																																				
D	2010	CTS	Body	Instrument Panel Cluster (Other)	V	V																		V	V																																				
D	2010	CTS	Body	Liftgate Module	V	V																			V																																				
D	2010	CTS	Body	Memory Seat Module	V	V																		V	V																																				
D	2010	CTS	Body	Park Assist Module	V	V																		V	V																																				
D	2010	CTS	Body	Passenger Door Switch	V	V																		V	V																																				
D	2010	CTS	Body	Passenger Presence System	V	V																			V																																				
D	2010	CTS	Body	Pedestrian Impact Detection Module	V	V																			V																																				
D	2010	CTS	Body	Radio	V	V																		V	V																																				
D	2010	CTS	Body	Supplemental Inflatable Restraint	V	V																			V																																				
D	2010	CTS	Body	TV Antenna Module	V	V																			V																																				
D	2010	CTS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
D	2010	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V																
D	2010	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module	V	V																		V										V	V	V																								
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V		V														
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V										V	V	V																								
D	2010	STS	Chassis	Electronic Brake Control Module With (RPO JL7)	V	V																		V	V																																				
D	2010	STS	Chassis	Electronic Suspension Control With (RPO JL7)	V	V																		V	V																																				
D	2010	STS	Chassis	Power Steering Control Module With (RPO JL7)	V	V																																																						
D	2010	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)	V	V																																																						
D	2010	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)	V	V																		V	V																																				
D	2010	STS	Chassis	Electronic Suspension Control Without (RPO JL7)	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2010	STS	Body	Amplifier (Bose)	V	V																		V																																						
D	2010	STS	Body	Digital Radio Receiver	V	V																		V																																						
D	2010	STS	Body	Distance Sensing Cruise Control	V	V																			V																																					
D	2010	STS	Body	Driver Door Module	V	V																		V	V																																					
D	2010	STS	Body	Driver Door Switch	V	V																			V																																					
D	2010	STS	Body	Driver Position Module	V	V																		V	V																																					
D	2010	STS	Body	Headlamp Control Module	V	V																		V	V																																					
D	2010	STS	Body	Head Up Display	V	V																		V	V																																					
D	2010	STS	Body	HVAC Control Module	V	V																		V	V																																					
D	2010	STS	Body	Instrument Panel Cluster	V	V																		V	V																																					
D	2010	STS	Body	Instrument Panel Module	V	V																		V	V																																					
D	2010	STS	Body	Left Rear Door Module	V	V																		V	V																																					
D	2010	STS	Body	Left Side Object Detection Module	V	V																		V	V																																					
D	2010	STS	Body	Passenger Door Module	V	V																		V	V																																					
D	2010	STS	Body	Uplevel Radio	V	V																			V																																					
D	2010	STS	Body	Navigation Radio	V	V																		V	V																																					
D	2010	STS	Body	Rear Integration Module	V	V																		V	V																																					
D	2010	STS	Body	Remote Control Door Lock Receiver	V	V																		V	V																																					
D	2010	STS	Body	Right Rear Door Module	V	V																		V	V																																					
D	2010	STS	Body	Right Side Object Detection Module	V	V																			V																																					
D	2010	STS	Body	Steering Column Lock Module	V	V																		V	V																																					
D	2010	STS	Body	Supplemental Inflatable Restraint	V	V																			V																																					
D	2010	STS	Body	TV Antenna Module	V	V																			V																																					
D	2010	STS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																					
D	2010	STS	Body	Veh Direction Alert Alarm Warn Mod	V	V																			V																																					
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto	V	V	V						V			V	V	V	V		V	V		V	V							V														V															
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V							V														V															
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module	V	V																		V	V																																					
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module	V	V																		V											V	V	V																									
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Auto	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V															
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Manual	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V	V	V															
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module	V	V																		V											V	V	V																									
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module	V	V																		V	V																																					
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transfer Case Control Module	V	V																		V	V																																					
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V																		
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transmission Control Module	V	V																		V											V	V	V																									
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Fuel Pump Control Module	V	V																		V	V																																					
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transfer Case Control Module	V	V																		V	V																																					
D	2011	CTS	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
D	2011	CTS	Chassis	Electronic Suspension Control	V	V																		V																																						
D	2011	CTS	Chassis	Parking Brake Control Module	V	V																		V	V																																					
D	2011	CTS	Body	Body Control Module (6.2L V8 LSA)	V	V																		V	V																																					
D	2011	CTS	Body	Body Control Module (Other)	V	V																		V	V																																					
D	2011	CTS	Body	Body Control Module (aux.)	V	V																		V	V																																					
D	2011	CTS	Body	Driver Door Switch	V	V																		V	V																																					
D	2011	CTS	Body	Headlamp Control Module	V	V																		V	V																																					
D	2011	CTS	Body	HVAC Control Module	V	V																		V	V																																					
D	2011	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)	V	V																		V	V																																					
D	2011	CTS	Body	Instrument Panel Cluster (Other)	V	V																		V	V																																					
D	2011	CTS	Body	Liftgate Module	V	V																			V																																					
D	2011	CTS	Body	Memory Seat Module	V	V																		V	V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2011	CTS	Body	Park Assist Module	V	V																		V	V																																			
D	2011	CTS	Body	Passenger Door Switch	V	V																		V	V																																			
D	2011	CTS	Body	Passenger Presence System	V	V																			V																																			
D	2011	CTS	Body	Pedestrian Impact Detection Module	V	V																			V																																			
D	2011	CTS	Body	Radio	V	V																		V	V																																			
D	2011	CTS	Body	Supplemental Inflatable Restraint	V	V																			V																																			
D	2011	CTS	Body	TV Antenna Module	V	V																			V																																			
D	2011	CTS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
D	2011	STS	Powertrain	(D)3.6L V6 LLT Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V																
D	2011	STS	Powertrain	(D)3.6L V6 LLT Transmission Control Module	V	V																		V											V	V	V																							
D	2011	STS	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
D	2011	STS	Chassis	Electronic Suspension Control	V	V																		V	V																																			
D	2011	STS	Body	Amplifier (Bose)	V	V																		V																																				
D	2011	STS	Body	Digital Radio Receiver	V	V																		V																																				
D	2011	STS	Body	Distance Sensing Cruise Control	V	V																			V																																			
D	2011	STS	Body	Driver Door Module	V	V																		V	V																																			
D	2011	STS	Body	Driver Door Switch	V	V																			V																																			
D	2011	STS	Body	Driver Position Module	V	V																		V	V																																			
D	2011	STS	Body	Headlamp Control Module	V	V																		V	V																																			
D	2011	STS	Body	Head Up Display	V	V																		V	V																																			
D	2011	STS	Body	HVAC Control Module	V	V																		V	V																																			
D	2011	STS	Body	Instrument Panel Cluster	V	V																		V	V																																			
D	2011	STS	Body	Instrument Panel Module	V	V																		V	V																																			
D	2011	STS	Body	Left Rear Door Module	V	V																		V	V																																			
D	2011	STS	Body	Left Side Object Detection Module	V	V																		V	V																																			
D	2011	STS	Body	Passenger Door Module	V	V																		V	V																																			
D	2011	STS	Body	Uplevel Radio	V	V																			V																																			
D	2011	STS	Body	Navigation Radio	V	V																		V	V																																			
D	2011	STS	Body	Rear Integration Module	V	V																		V	V																																			
D	2011	STS	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
D	2011	STS	Body	Right Rear Door Module	V	V																		V	V																																			
D	2011	STS	Body	Right Side Object Detection Module	V	V																			V																																			
D	2011	STS	Body	Supplemental Inflatable Restraint	V	V																			V																																			
D	2011	STS	Body	TV Antenna Module	V	V																			V																																			
D	2011	STS	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
D	2011	STS	Body	Veh Direction Alert Alarm Warn Mod	V	V																			V																																			
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V							V												V	V													
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module	V	V																		V	V																																			
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module	V	V																		V											V	V	V																							
D	2012	P Type Engine	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
D	2012	P Type Engine	Chassis	Electronic Suspension Control	V	V																		V																																				
D	2012	P Type Engine	Chassis	Parking Brake Control Module	V	V																		V	V																																			
D	2012	P Type Engine	Body	Body Control Module	V	V																		V	V																																			
D	2012	P Type Engine	Body	Body Control Module (aux.)	V	V																		V	V																																			
D	2012	P Type Engine	Body	Driver Door Switch	V	V																		V	V																																			
D	2012	P Type Engine	Body	Headlamp Control Module	V	V																		V	V																																			
D	2012	P Type Engine	Body	HVAC Control Module	V	V																		V	V																																			
D	2012	P Type Engine	Body	Instrument Panel Cluster	V	V																		V	V																																			
D	2012	P Type Engine	Body	Left Side Object Detection Module	V	V																		V	V																																			
D	2012	P Type Engine	Body	Liftgate Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2012	P Type Engine	Body	Memory Seat Module	V	V																		V	V																																			
D	2012	P Type Engine	Body	Park Assist Module	V	V																		V	V																																			
D	2012	P Type Engine	Body	Passenger Door Switch	V	V																		V	V																																			
D	2012	P Type Engine	Body	Passenger Presence System	V	V																			V																																			
D	2012	P Type Engine	Body	Pedestrian Impact Detection Module	V	V																			V																																			
D	2012	P Type Engine	Body	Radio	V	V																		V	V																																			
D	2012	P Type Engine	Body	Right Side Object Detection Module	V	V																			V																																			
D	2012	P Type Engine	Body	Supplemental Inflatable Restraint	V	V																			V																																			
D	2012	P Type Engine	Body	TV Antenna Module	V	V																			V																																			
D	2012	P Type Engine	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V													
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V	V	V													
D	2012	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module	V	V																		V	V																																			
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module	V	V																		V											V	V	V																							
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module	V	V																		V	V																																			
D	2012	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V													
D	2012	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module	V	V																		V	V																																			
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module	V	V																		V											V	V	V																							
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module	V	V																		V	V																																			
D	2012	Other	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
D	2012	Other	Chassis	Electronic Suspension Control	V	V																		V																																				
D	2012	Other	Chassis	Parking Brake Control Module	V	V																		V	V																																			
D	2012	Other	Body	Body Control Module	V	V																		V	V																																			
D	2012	Other	Body	Body Control Module (aux.)	V	V																		V	V																																			
D	2012	Other	Body	Driver Door Switch	V	V																		V	V																																			
D	2012	Other	Body	Headlamp Control Module	V	V																		V	V																																			
D	2012	Other	Body	HVAC Control Module	V	V																		V	V																																			
D	2012	Other	Body	Instrument Panel Cluster	V	V																		V	V																																			
D	2012	Other	Body	Left Side Object Detection Module	V	V																		V	V																																			
D	2012	Other	Body	Liftgate Module	V	V																			V																																			
D	2012	Other	Body	Memory Seat Module	V	V																		V	V																																			
D	2012	Other	Body	Park Assist Module	V	V																		V	V																																			
D	2012	Other	Body	Passenger Door Switch	V	V																		V	V																																			
D	2012	Other	Body	Passenger Presence System	V	V																			V																																			
D	2012	Other	Body	Pedestrian Impact Detection Module	V	V																			V																																			
D	2012	Other	Body	Radio	V	V																		V	V																																			
D	2012	Other	Body	Right Side Object Detection Module	V	V																			V																																			
D	2012	Other	Body	Supplemental Inflatable Restraint	V	V																			V																																			
D	2012	Other	Body	TV Antenna Module	V	V																			V																																			
D	2012	Other	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V							V												V	V													
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module	V	V																		V	V																																			
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module	V	V																		V											V	V	V																							
D	2013	P Type Engine	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
D	2013	P Type Engine	Chassis	Electronic Suspension Control	V	V																		V																																				
D	2013	P Type Engine	Chassis	Parking Brake Control Module	V	V																		V	V																																			
D	2013	P Type Engine	Body	Body Control Module	V	V																		V	V																																			
D	2013	P Type Engine	Body	Body Control Module (aux.)	V	V																		V	V																																			
D	2013	P Type Engine	Body	Driver Door Switch	V	V																		V	V																																			
D	2013	P Type Engine	Body	Headlamp Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2013	P Type Engine	Body	HVAC Control Module	V	V																		V	V																																			
D	2013	P Type Engine	Body	Instrument Panel Cluster	V	V																		V	V																																			
D	2013	P Type Engine	Body	Left Side Object Detection Module	V	V																		V	V																																			
D	2013	P Type Engine	Body	Liftgate Module	V	V																			V																																			
D	2013	P Type Engine	Body	Memory Seat Module	V	V																		V	V																																			
D	2013	P Type Engine	Body	Park Assist Module	V	V																		V	V																																			
D	2013	P Type Engine	Body	Passenger Door Switch	V	V																		V	V																																			
D	2013	P Type Engine	Body	Passenger Presence System	V	V																			V																																			
D	2013	P Type Engine	Body	Pedestrian Impact Detection Module	V	V																			V																																			
D	2013	P Type Engine	Body	Radio	V	V																		V	V																																			
D	2013	P Type Engine	Body	Right Side Object Detection Module	V	V																			V																																			
D	2013	P Type Engine	Body	Supplemental Inflatable Restraint	V	V																			V																																			
D	2013	P Type Engine	Body	TV Antenna Module	V	V																			V																																			
D	2013	P Type Engine	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto	V	V	V					V		V	V	V	V	V		V	V			V	V							V								V	V	V	V		V														
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual	V	V	V					V		V	V	V	V	V		V	V			V	V							V								V	V	V	V	V	V														
D	2013	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module	V	V																		V	V																																			
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module	V	V																		V										V	V	V																								
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module	V	V																		V	V																																			
D	2013	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module	V	V	V					V		V	V	V	V	V		V	V			V	V							V								V	V	V	V		V														
D	2013	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module	V	V																		V	V																																			
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module	V	V																		V										V	V	V																								
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module	V	V																		V	V																																			
D	2013	Other	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
D	2013	Other	Chassis	Electronic Suspension Control	V	V																		V																																				
D	2013	Other	Chassis	Parking Brake Control Module	V	V																		V	V																																			
D	2013	Other	Body	Body Control Module	V	V																		V	V																																			
D	2013	Other	Body	Body Control Module (aux.)	V	V																		V	V																																			
D	2013	Other	Body	Driver Door Switch	V	V																		V	V																																			
D	2013	Other	Body	Headlamp Control Module	V	V																		V	V																																			
D	2013	Other	Body	HVAC Control Module	V	V																		V	V																																			
D	2013	Other	Body	Instrument Panel Cluster	V	V																		V	V																																			
D	2013	Other	Body	Left Side Object Detection Module	V	V																		V	V																																			
D	2013	Other	Body	Liftgate Module	V	V																			V																																			
D	2013	Other	Body	Memory Seat Module	V	V																		V	V																																			
D	2013	Other	Body	Park Assist Module	V	V																		V	V																																			
D	2013	Other	Body	Passenger Door Switch	V	V																		V	V																																			
D	2013	Other	Body	Passenger Presence System	V	V																			V																																			
D	2013	Other	Body	Pedestrian Impact Detection Module	V	V																			V																																			
D	2013	Other	Body	Radio	V	V																		V	V																																			
D	2013	Other	Body	Right Side Object Detection Module	V	V																			V																																			
D	2013	Other	Body	Supplemental Inflatable Restraint	V	V																			V																																			
D	2013	Other	Body	TV Antenna Module	V	V																			V																																			
D	2013	Other	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V														
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V								V	V	V	V	V	V														
D	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V													
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V													
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V											V	V													
D	2014	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module	V	V																		V	V									V	V	V	V										V											
D	2014	CTS	Powertrain	Chassis Control Module	V	V																		V	V							V																											

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2014	CTS	Powertrain	Transfer Case Control Module	V	V																		V	V																																				
D	2014	CTS	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
D	2014	CTS	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
D	2014	CTS	Chassis	Suspension Control Module	V	V																		V	V																																		
D	2014	CTS	Body	Body Control Module Coupe	V	V																		V	V																																		
D	2014	CTS	Body	Body Control Module Station Wagon	V	V																		V	V																																		
D	2014	CTS	Body	Auxiliary Body Control Module	V	V																		V	V																																		
D	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
D	2014	CTS	Body	Passenger Presence Module	V	V																			V																																	
D	2014	CTS	Body	Pedestrian Impact Detection Module	V	V																																																				
D	2014	CTS	Body	Instrument Cluster	V	V																		V	V																																		
D	2014	CTS	Body	Headlamp Control Module	V	V																		V	V																																		
D	2014	CTS	Body	Radio	V	V																		V	V																																		
D	2014	CTS	Body	Amplifier	V	V																			V																																	
D	2014	CTS	Body	Television Antenna Module	V																																																				
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
D	2014	CTS	Body	HVAC Control Module	V	V																		V	V																																		
D	2014	CTS	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V												
D	2014	CTS	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
D	2014	CTS	Body	Liftgate Control Module	V	V																			V																						V												
D	2014	CTS	Body	Seat Memory Control Module	V	V																		V	V																																		
D	2014	CTS	Body	Right Side Object Detection Control Module	V	V																		V	V																																		
D	2014	CTS	Body	Left Side Object Detection Control Module	V	V																		V	V																																		
D	2014	CTS	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)	V	V																		V	V																																		
D	2014	CTS	Body	Remote Control Keyless Type Standard Range (ATG)	V	V																		V	V																																		
D	2014	CTS	Body	Parking Assist Control Module	V																			V	V																																		
D	2014	CTS	Body	Theft Deterrent Module	V	V																			V																																		
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V												V														
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V	V													
D	2015	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module	V	V																		V	V									V	V	V	V									V												
D	2015	CTS	Powertrain	Chassis Control Module	V	V																		V	V							V																										
D	2015	CTS	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
D	2015	CTS	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
D	2015	CTS	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
D	2015	CTS	Chassis	Suspension Control Module	V	V																		V	V																																		
D	2015	CTS	Body	Body Control Module Coupe	V	V																		V	V																																		
D	2015	CTS	Body	Body Control Module Station Wagon	V	V																		V	V																																		
D	2015	CTS	Body	Auxiliary Body Control Module	V	V																		V	V																																		
D	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
D	2015	CTS	Body	Passenger Presence Module	V	V																			V																																	
D	2015	CTS	Body	Pedestrian Impact Detection Module	V	V																																																			
D	2015	CTS	Body	Instrument Cluster	V	V																		V	V																																		
D	2015	CTS	Body	Headlamp Control Module	V	V																		V	V																																		
D	2015	CTS	Body	Radio	V	V																		V	V																																		
D	2015	CTS	Body	Amplifier	V	V																			V																																	
D	2015	CTS	Body	Television Antenna Module	V																																																				
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
D	2015	CTS	Body	HVAC Control Module	V	V																		V	V																																		
D	2015	CTS	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2015	CTS	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																				
D	2015	CTS	Body	Liftgate Control Module	V	V																			V																					V													
D	2015	CTS	Body	Seat Memory Control Module	V	V																		V	V																																			
D	2015	CTS	Body	Right Side Object Detection Control Module	V	V																		V	V																																			
D	2015	CTS	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
D	2015	CTS	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
D	2015	CTS	Body	Parking Assist Control Module	V																			V	V																																			
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module	V	V							V			V					V			V	V						V													V															
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module	V	V																		V										V	V																								
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module	V	V							V			V					V			V	V						V													V															
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module	V	V																		V										V	V																								
K	2004	(KD)Deville	Body	Amplifier (Delco)	V	V																		V																																				
K	2004	(KD)Deville	Body	CD Changer	V	V																																																					
K	2004	(KD)Deville	Body	Dash Integration Module	V	V																		V																																				
K	2004	(KD)Deville	Body	Digital Radio Receiver	V	V																			V																																			
K	2004	(KD)Deville	Body	Driver Door Switch	V	V																																																					
K	2004	(KD)Deville	Body	Driver Door Module	V	V																		V																																				
K	2004	(KD)Deville	Body	Passenger Door Module	V	V																		V																																				
K	2004	(KD)Deville	Body	Left Rear Door Module	V	V																		V																																				
K	2004	(KD)Deville	Body	Right Rear Door Module	V	V																		V																																				
K	2004	(KD)Deville	Body	Instrument Panel Cluster	V	V																		V																																				
K	2004	(KD)Deville	Body	Instrument Panel Module	V	V																		V																																				
K	2004	(KD)Deville	Body	Memory Seat Module	V	V																		V																																				
K	2004	(KD)Deville	Body	Navigation Radio	V	V																																																					
K	2004	(KD)Deville	Body	Radio	V	V																		V																																				
K	2004	(KD)Deville	Body	Rear Climate Control Panel	V	V																		V																																				
K	2004	(KD)Deville	Body	Rear Integration Module	V	V																		V																																				
K	2004	(KD)Deville	Body	Remote Function Actuation	V	V																																																					
K	2004	(KD)Deville	Body	Supplemental Inflatable Restraint	V	V																																																					
K	2004	(KD)Deville	Body	Tilt Telescope Module	V	V																		V																																				
K	2004	(KD)Deville	Body	Vehicle Theft Deterrent	V	V																																																					
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module	V	V							V			V					V			V	V						V													V															
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module	V	V																		V										V	V																								
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module	V	V							V			V					V			V	V						V													V															
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module	V	V																		V										V	V																								
K	2004	(KE)DHS	Body	Amplifier (Bose)	V	V																		V																																				
K	2004	(KE)DHS	Body	CD Changer	V	V																																																					
K	2004	(KE)DHS	Body	Dash Integration Module	V	V																		V																																				
K	2004	(KE)DHS	Body	Digital Radio Receiver	V	V																			V																																			
K	2004	(KE)DHS	Body	Driver Door Switch	V	V																																																					
K	2004	(KE)DHS	Body	Driver Door Module	V	V																		V																																				
K	2004	(KE)DHS	Body	Passenger Door Module	V	V																		V																																				
K	2004	(KE)DHS	Body	Left Rear Door Module	V	V																		V																																				
K	2004	(KE)DHS	Body	Right Rear Door Module	V	V																		V																																				
K	2004	(KE)DHS	Body	Instrument Panel Cluster	V	V																		V																																				
K	2004	(KE)DHS	Body	Instrument Panel Module	V	V																		V																																				
K	2004	(KE)DHS	Body	Memory Seat Module	V	V																		V																																				
K	2004	(KE)DHS	Body	Navigation Radio	V	V																																																					
K	2004	(KE)DHS	Body	Radio	V	V																		V																																				
K	2004	(KE)DHS	Body	Rear Climate Control Panel	V	V																		V																																				
K	2004	(KE)DHS	Body	Rear Integration Module	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2004	(KE)DHS	Body	Remote Function Actuation	V	V																																																						
K	2004	(KE)DHS	Body	Supplemental Inflatable Restraint	V	V																																																						
K	2004	(KE)DHS	Body	Tilt Telescope Module	V	V																	V																																					
K	2004	(KE)DHS	Body	Vehicle Theft Deterrent	V	V																																																						
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module	V	V							V			V					V			V	V							V													V															
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module	V	V																		V											V	V																								
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module	V	V							V			V					V			V	V							V													V															
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module	V	V																		V											V	V																								
K	2004	(KF)DTS	Body	Amplifier (Bose)	V	V																		V																																				
K	2004	(KF)DTS	Body	CD Changer	V	V																																																						
K	2004	(KF)DTS	Body	Dash Integration Module	V	V																		V																																				
K	2004	(KF)DTS	Body	Digital Radio Receiver	V	V																			V																																			
K	2004	(KF)DTS	Body	Driver Door Switch	V	V																																																						
K	2004	(KF)DTS	Body	Driver Door Module	V	V																		V																																				
K	2004	(KF)DTS	Body	Passenger Door Module	V	V																		V																																				
K	2004	(KF)DTS	Body	Left Rear Door Module	V	V																		V																																				
K	2004	(KF)DTS	Body	Right Rear Door Module	V	V																		V																																				
K	2004	(KF)DTS	Body	Instrument Panel Cluster	V	V																		V																																				
K	2004	(KF)DTS	Body	Instrument Panel Module	V	V																		V																																				
K	2004	(KF)DTS	Body	Memory Seat Module	V	V																		V																																				
K	2004	(KF)DTS	Body	Navigation Radio	V	V																																																						
K	2004	(KF)DTS	Body	Radio	V	V																		V																																				
K	2004	(KF)DTS	Body	Rear Climate Control Panel	V	V																		V																																				
K	2004	(KF)DTS	Body	Rear Integration Module	V	V																		V																																				
K	2004	(KF)DTS	Body	Remote Function Actuation	V	V																																																						
K	2004	(KF)DTS	Body	Supplemental Inflatable Restraint	V	V																																																						
K	2004	(KF)DTS	Body	Tilt Telescope Module	V	V																		V																																				
K	2004	(KF)DTS	Body	Vehicle Theft Deterrent	V	V																																																						
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Engine Control Module	V	V							V			V					V			V	V							V													V															
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Transmission Control Module	V	V																		V											V	V																								
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module	V	V							V			V					V			V	V							V													V															
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module	V	V																		V											V	V																								
K	2004	(KS)Seville SLS	Body	Amplifier (Bose)	V	V																		V																																				
K	2004	(KS)Seville SLS	Body	Amplifier (Delco)	V	V																		V																																				
K	2004	(KS)Seville SLS	Body	CD Changer	V	V																																																						
K	2004	(KS)Seville SLS	Body	Dash Integration Module	V	V																		V																																				
K	2004	(KS)Seville SLS	Body	Digital Radio Receiver	V	V																			V																																			
K	2004	(KS)Seville SLS	Body	Driver Door Module	V	V																		V																																				
K	2004	(KS)Seville SLS	Body	Instrument Panel Cluster	V	V																		V																																				
K	2004	(KS)Seville SLS	Body	Instrument Panel Module	V	V																		V																																				
K	2004	(KS)Seville SLS	Body	Memory Seat Module	V	V																		V																																				
K	2004	(KS)Seville SLS	Body	Navigation Radio	V	V																																																						
K	2004	(KS)Seville SLS	Body	Radio	V	V																		V																																				
K	2004	(KS)Seville SLS	Body	Rear Integration Module	V	V																		V																																				
K	2004	(KS)Seville SLS	Body	Remote Function Actuation	V	V																																																						
K	2004	(KS)Seville SLS	Body	Supplemental Inflatable Restraint	V	V																																																						
K	2004	(KS)Seville SLS	Body	Tilt Telescope Module	V	V																		V																																				
K	2004	(KS)Seville SLS	Body	Vehicle Theft Deterrent	V	V																																																						
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Engine Control Module	V	V							V			V					V			V	V							V													V															
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Transmission Control Module	V	V																		V											V	V																								
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module	V	V							V			V					V			V	V							V													V															

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module	V	V																		V										V	V																									
K	2004	(KY)Seville STS	Body	Amplifier (Bose)	V	V																		V																																				
K	2004	(KY)Seville STS	Body	Amplifier (Delco)	V	V																		V																																				
K	2004	(KY)Seville STS	Body	CD Changer	V	V																																																					
K	2004	(KY)Seville STS	Body	Dash Integration Module	V	V																		V																																				
K	2004	(KY)Seville STS	Body	Digital Radio Receiver	V	V																			V																																			
K	2004	(KY)Seville STS	Body	Driver Door Module	V	V																		V																																				
K	2004	(KY)Seville STS	Body	Instrument Panel Cluster	V	V																		V																																				
K	2004	(KY)Seville STS	Body	Instrument Panel Module	V	V																		V																																				
K	2004	(KY)Seville STS	Body	Memory Seat Module	V	V																		V																																				
K	2004	(KY)Seville STS	Body	Navigation Radio	V	V																																																						
K	2004	(KY)Seville STS	Body	Radio	V	V																		V																																				
K	2004	(KY)Seville STS	Body	Rear Integration Module	V	V																		V																																				
K	2004	(KY)Seville STS	Body	Remote Function Actuation	V	V																																																						
K	2004	(KY)Seville STS	Body	Supplemental Inflatable Restraint	V	V																																																					
K	2004	(KY)Seville STS	Body	Tilt Telescope Module	V	V																		V																																				
K	2004	(KY)Seville STS	Body	Vehicle Theft Deterrent	V	V																																																					
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module	V	V							V			V					V			V	V							V														V													
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module	V	V																		V										V	V																								
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module	V	V							V			V					V			V	V							V														V													
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module	V	V																		V										V	V																								
K	2005	(KD)Deville	Body	Amplifier (Delco)	V	V																		V																																				
K	2005	(KD)Deville	Body	CD Changer	V	V																																																					
K	2005	(KD)Deville	Body	Dash Integration Module	V	V																		V																																				
K	2005	(KD)Deville	Body	Digital Radio Receiver	V	V																			V																																			
K	2005	(KD)Deville	Body	Driver Door Switch	V	V																																																					
K	2005	(KD)Deville	Body	Driver Door Module	V	V																		V																																				
K	2005	(KD)Deville	Body	Passenger Door Module	V	V																		V																																				
K	2005	(KD)Deville	Body	Left Rear Door Module	V	V																		V																																				
K	2005	(KD)Deville	Body	Right Rear Door Module	V	V																		V																																				
K	2005	(KD)Deville	Body	Instrument Panel Cluster	V	V																		V																																				
K	2005	(KD)Deville	Body	Instrument Panel Module	V	V																		V																																				
K	2005	(KD)Deville	Body	Memory Seat Module	V	V																		V																																				
K	2005	(KD)Deville	Body	Navigation Radio	V	V																																																					
K	2005	(KD)Deville	Body	Radio	V	V																		V																																				
K	2005	(KD)Deville	Body	Rear Climate Control Panel	V	V																		V																																				
K	2005	(KD)Deville	Body	Rear Integration Module	V	V																		V																																				
K	2005	(KD)Deville	Body	Remote Function Actuation	V	V																																																					
K	2005	(KD)Deville	Body	Supplemental Inflatable Restraint	V	V																																																					
K	2005	(KD)Deville	Body	Tilt Telescope Module	V	V																		V																																				
K	2005	(KD)Deville	Body	Vehicle Theft Deterrent	V	V																																																					
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module	V	V							V			V					V			V	V							V														V													
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module	V	V																		V										V	V																								
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module	V	V							V			V					V			V	V							V														V													
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module	V	V																		V										V	V																								
K	2005	(KE)DHS	Body	Amplifier (Bose)	V	V																		V																																				
K	2005	(KE)DHS	Body	CD Changer	V	V																																																					
K	2005	(KE)DHS	Body	Dash Integration Module	V	V																		V																																				
K	2005	(KE)DHS	Body	Digital Radio Receiver	V	V																			V																																			
K	2005	(KE)DHS	Body	Driver Door Switch	V	V																																																					
K	2005	(KE)DHS	Body	Driver Door Module	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2005	(KE)DHS	Body	Passenger Door Module	V	V																		V																																				
K	2005	(KE)DHS	Body	Left Rear Door Module	V	V																		V																																				
K	2005	(KE)DHS	Body	Right Rear Door Module	V	V																		V																																				
K	2005	(KE)DHS	Body	Instrument Panel Cluster	V	V																		V																																				
K	2005	(KE)DHS	Body	Instrument Panel Module	V	V																		V																																				
K	2005	(KE)DHS	Body	Memory Seat Module	V	V																		V																																				
K	2005	(KE)DHS	Body	Navigation Radio	V	V																																																						
K	2005	(KE)DHS	Body	Radio	V	V																		V																																				
K	2005	(KE)DHS	Body	Rear Climate Control Panel	V	V																		V																																				
K	2005	(KE)DHS	Body	Rear Integration Module	V	V																		V																																				
K	2005	(KE)DHS	Body	Remote Function Actuation	V	V																																																						
K	2005	(KE)DHS	Body	Supplemental Inflatable Restraint	V	V																																																						
K	2005	(KE)DHS	Body	Tilt Telescope Module	V	V																		V																																				
K	2005	(KE)DHS	Body	Vehicle Theft Deterrent	V	V																																																						
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module	V	V							V			V					V			V	V							V													V															
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module	V	V																		V										V	V																									
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module	V	V							V			V					V			V	V							V													V															
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module	V	V																		V										V	V																									
K	2005	(KF)DTS	Body	Amplifier (Bose)	V	V																		V																																				
K	2005	(KF)DTS	Body	CD Changer	V	V																																																						
K	2005	(KF)DTS	Body	Dash Integration Module	V	V																		V																																				
K	2005	(KF)DTS	Body	Digital Radio Receiver	V	V																			V																																			
K	2005	(KF)DTS	Body	Driver Door Switch	V	V																																																						
K	2005	(KF)DTS	Body	Driver Door Module	V	V																		V																																				
K	2005	(KF)DTS	Body	Passenger Door Module	V	V																		V																																				
K	2005	(KF)DTS	Body	Left Rear Door Module	V	V																		V																																				
K	2005	(KF)DTS	Body	Right Rear Door Module	V	V																		V																																				
K	2005	(KF)DTS	Body	Instrument Panel Cluster	V	V																		V																																				
K	2005	(KF)DTS	Body	Instrument Panel Module	V	V																		V																																				
K	2005	(KF)DTS	Body	Memory Seat Module	V	V																		V																																				
K	2005	(KF)DTS	Body	Navigation Radio	V	V																																																						
K	2005	(KF)DTS	Body	Radio	V	V																		V																																				
K	2005	(KF)DTS	Body	Rear Climate Control Panel	V	V																		V																																				
K	2005	(KF)DTS	Body	Rear Integration Module	V	V																		V																																				
K	2005	(KF)DTS	Body	Remote Function Actuation	V	V																																																						
K	2005	(KF)DTS	Body	Supplemental Inflatable Restraint	V	V																																																						
K	2005	(KF)DTS	Body	Tilt Telescope Module	V	V																		V																																				
K	2005	(KF)DTS	Body	Vehicle Theft Deterrent	V	V																																																						
K	2006	ALL	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V															
K	2006	ALL	Powertrain	Automatic Transaxle	V	V																		V										V	V																									
K	2006	ALL	Chassis	Antilock Brake System	V	V																			V																																			
K	2006	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2006	ALL	Body	Aux. HVAC Control Module		V																		V	V																																			
K	2006	ALL	Body	Body Control Module	V	V																			V																																			
K	2006	ALL	Body	Digital Radio Receiver	V	V																			V																																			
K	2006	ALL	Body	Distance Sensing Cruise Control	V	V																			V																																			
K	2006	ALL	Body	Driver Door Switch	V	V																		V	V																																			
K	2006	ALL	Body	Driver Position Module	V	V																		V	V																																			
K	2006	ALL	Body	HVAC Control Module	V	V																		V	V																																			
K	2006	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2006	ALL	Body	Park Assist Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2006	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
K	2006	ALL	Body	Passenger Presence System	V	V																			V																																			
K	2006	ALL	Body	Radio	V	V																		V	V																																			
K	2006	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
K	2006	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
K	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2006	ALL	Body	Theft Deterrent Module	V	V																			V																																			
K	2006	ALL	Body	TV Antenna Module	V	V																			V																																			
K	2006	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
K	2007	ALL	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2007	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																							
K	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2007	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2007	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)		V																		V	V																																			
K	2007	ALL	Body	Body Control Module	V	V																		V	V																																			
K	2007	ALL	Body	Digital Radio Receiver	V	V																			V																																			
K	2007	ALL	Body	Distance Sensing Cruise Control	V	V																			V																																			
K	2007	ALL	Body	Driver Door Switch	V	V																		V	V																																			
K	2007	ALL	Body	Driver Position Module	V	V																		V	V																																			
K	2007	ALL	Body	CJ2 Dual Zone HVAC Auto	V	V																		V	V																																			
K	2007	ALL	Body	CJ4 Tri Zone HVAC Auto	V	V																		V	V																																			
K	2007	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
K	2007	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2007	ALL	Body	Park Assist Module	V	V																		V	V																																			
K	2007	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
K	2007	ALL	Body	Passenger Presence System	V	V																			V																																			
K	2007	ALL	Body	Radio	V	V																		V	V																																			
K	2007	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
K	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2007	ALL	Body	Theft Deterrent Module	V	V																			V																																			
K	2007	ALL	Body	TV Antenna Module	V	V																			V																																			
K	2007	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
K	2008	ALL	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																							
K	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2008	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2008	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)		V																		V	V																																			
K	2008	ALL	Body	Body Control Module	V	V																		V	V																																			
K	2008	ALL	Body	Digital Radio Receiver	V	V																			V																																			
K	2008	ALL	Body	Distance Sensing Cruise Control	V	V																			V																																			
K	2008	ALL	Body	Driver Door Switch	V	V																		V	V																																			
K	2008	ALL	Body	Driver Position Module	V	V																		V	V																																			
K	2008	ALL	Body	CJ2 Dual Zone HVAC Auto	V	V																		V	V																																			
K	2008	ALL	Body	CJ4 Tri Zone HVAC Auto	V	V																		V	V																																			
K	2008	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
K	2008	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2008	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2008	ALL	Body	Park Assist Module	V	V																		V	V																																			
K	2008	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
K	2008	ALL	Body	Passenger Presence System	V	V																			V																																			
K	2008	ALL	Body	Radio	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2008	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
K	2008	ALL	Body	Right Side Object Detection Module	V	V																			V																																			
K	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2008	ALL	Body	Theft Deterrent Module	V	V																			V																																			
K	2008	ALL	Body	TV Antenna Module	V	V																			V																																			
K	2008	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
K	2008	ALL	Body	Veh Direction Alert Alarm Warn Mod	V	V																			V																																			
K	2009	ALL	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2009	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																							
K	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2009	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2009	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)		V																		V	V																																			
K	2009	ALL	Body	Body Control Module	V	V																		V	V																																			
K	2009	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2009	ALL	Body	Distance Sensing Cruise Control	V	V																			V																																			
K	2009	ALL	Body	Driver Door Switch	V	V																		V	V																																			
K	2009	ALL	Body	Driver Position Module	V	V																		V	V																																			
K	2009	ALL	Body	CJ2 Dual Zone HVAC Auto	V	V																		V	V																																			
K	2009	ALL	Body	CJ4 Tri Zone HVAC Auto	V	V																		V	V																																			
K	2009	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
K	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2009	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2009	ALL	Body	Park Assist Module	V	V																		V	V																																			
K	2009	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
K	2009	ALL	Body	Passenger Presence System	V	V																			V																																			
K	2009	ALL	Body	Radio	V	V																		V	V																																			
K	2009	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
K	2009	ALL	Body	Right Side Object Detection Module	V	V																			V																																			
K	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																			
K	2009	ALL	Body	TV Antenna Module	V	V																			V																																			
K	2009	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
K	2009	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
K	2009	ALL	Body	Veh Direction Alert Alarm Warn Mod	V	V																			V																																			
K	2010	ALL	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2010	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																							
K	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2010	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2010	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)		V																		V	V																																			
K	2010	ALL	Body	Body Control Module	V	V																		V	V																																			
K	2010	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2010	ALL	Body	Distance Sensing Cruise Control	V	V																			V																																			
K	2010	ALL	Body	Driver Door Switch	V	V																		V	V																																			
K	2010	ALL	Body	Driver Position Module	V	V																		V	V																																			
K	2010	ALL	Body	CJ2 Dual Zone HVAC Auto	V	V																		V	V																																			
K	2010	ALL	Body	CJ4 Tri Zone HVAC Auto	V	V																		V	V																																			
K	2010	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
K	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2010	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2010	ALL	Body	Park Assist Module	V	V																		V	V																																			
K	2010	ALL	Body	Passenger Door Switch	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2010	ALL	Body	Passenger Presence System	V	V																			V																																			
K	2010	ALL	Body	Radio	V	V																		V	V																																		
K	2010	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
K	2010	ALL	Body	Right Side Object Detection Module	V	V																			V																																			
K	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2010	ALL	Body	Theft Deterrent Module	V	V																			V																																			
K	2010	ALL	Body	TV Antenna Module	V	V																			V																																			
K	2010	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
K	2010	ALL	Body	Veh Direction Alert Alarm Warn Mod	V	V																			V																																			
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Transmission Control Module	V	V																		V											V	V																							
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Transmission Control Module	V	V																		V											V	V																							
K	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2011	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2011	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)		V																		V	V																																			
K	2011	ALL	Body	Body Control Module	V	V																		V	V																																			
K	2011	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2011	ALL	Body	Distance Sensing Cruise Control	V	V																			V																																			
K	2011	ALL	Body	Driver Door Switch	V	V																		V	V																																			
K	2011	ALL	Body	Driver Position Module	V	V																		V	V																																			
K	2011	ALL	Body	CJ2 Dual Zone HVAC Auto	V	V																		V	V																																			
K	2011	ALL	Body	CJ4 Tri Zone HVAC Auto	V	V																		V	V																																			
K	2011	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
K	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2011	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2011	ALL	Body	Park Assist Module	V	V																		V	V																																			
K	2011	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
K	2011	ALL	Body	Passenger Presence System	V	V																			V																																			
K	2011	ALL	Body	Radio	V	V																		V	V																																			
K	2011	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
K	2011	ALL	Body	Right Side Object Detection Module	V	V																			V																																			
K	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2011	ALL	Body	Theft Deterrent Module	V	V																			V																																			
K	2011	ALL	Body	TV Antenna Module	V	V																			V																																			
K	2011	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
K	2011	ALL	Body	Veh Direction Alert Alarm Warn Mod	V	V																			V																																			
K	2016	CT6	Powertrain	(X) 2.0L LTG Engine Control Module	V																			V	V				V	V	V	V	V													V													
K	2016	CT6	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																		V	V										V	V	V	V		V																			
K	2016	CT6	Powertrain	(6) 3.0L LGW Engine Control Module	V																			V	V				V	V	V	V	V													V													
K	2016	CT6	Powertrain	(6) 3.0L LGW Transmission Control Module	V	V																		V	V										V	V	V	V		V																			
K	2016	CT6	Powertrain	(S) 3.6L LGX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
K	2016	CT6	Powertrain	(S) 3.6L LGX Transmission Control Module	V	V																		V	V										V	V	V	V		V																			
K	2016	CT6	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
K	2016	CT6	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V				V		
K	2016	CT6	Chassis	Brake Booster Control Module	V	V																			V																																			
K	2016	CT6	Chassis	Power Steering Control Module	V	V																			V																																			
K	2016	CT6	Chassis	Rear Wheel Steering Control Module	V	V																			V																																			
K	2016	CT6	Chassis	Suspension Control Module	V	V																		V	V																																			
K	2016	CT6	Body	Body Control Module	V	V																		V	V																																			
K	2016	CT6	Body	Serial Data Gateway Module	V																				V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2016	CT6	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
K	2016	CT6	Body	Passenger Presence Module	V	V																			V																																			
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Left	V	V																			V																																			
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Right	V	V																			V																																			
K	2016	CT6	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																		V	V																																			
K	2016	CT6	Body	Instrument Cluster Full Screen Display (UDV)	V	V																		V	V																																			
K	2016	CT6	Body	Radio Controls	V																				V																																			
K	2016	CT6	Body	HVAC Controls	V																			V	V																																			
K	2016	CT6	Body	Active Safety Control Module	V	V																		V	V																							V											
K	2016	CT6	Body	Video Processing Control Module	V	V																		V	V																																			
K	2016	CT6	Body	Headlamp Control Module	V	V																		V	V																							V											
K	2016	CT6	Body	Trailer Interface Control Module	V	V																		V	V																																			
K	2016	CT6	Body	Radio	V	V																		V	V																																			
K	2016	CT6	Body	Amplifier	V	V																			V																																			
K	2016	CT6	Body	Infotainment Control Touchpad	V																				V																																			
K	2016	CT6	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
K	2016	CT6	Body	Navigation Control Module	V	V																			V																																			
K	2016	CT6	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
K	2016	CT6	Body	HVAC Control Module	V	V																		V	V																																			
K	2016	CT6	Body	Liftgate Control Module	V	V																		V	V																							V											
K	2016	CT6	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
K	2016	CT6	Body	Seat Memory Control Module - Left Rear	V	V																		V	V																																			
K	2016	CT6	Body	Seat Memory Control Module - Driver	V																																																						
K	2016	CT6	Body	Seat Memory Control Module - Right Rear	V	V																		V	V																																			
K	2016	CT6	Body	Keyless Entry Control Module	V	V																		V	V																																			
K	2016	CT6	Body	Left Side Object Detection Control Module	V																			V	V																																			
K	2016	CT6	Body	Parking Assist Control Module	V																			V	V																																			
K	2016	CT6	Body	Frontview Camera Module	V	V																		V	V																																			
K	2016	CT6	Body	Long Range Radar Sensor Module	V	V																			V																																			
K	2016	CT6	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
K	2016	CT6	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
K	2016	CT6	Body	Rear Short Range Radar Sensor Module	V																				V																																			
K	2016	CT6	Body	Night Vision Camera Control Module	V	V																			V																																			
R	2014	ELR	Powertrain	Engine Control Module	V																			V	V	V	V	V	V	V	V	V																													
R	2014	ELR	Powertrain	Trasmission Control Module	V	V																		V	V										V		V	V									V											
R	2014	ELR	Powertrain	Chassis Control Module	V	V									V									V	V							V																											
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module	V	V	V																	V	V										V																							
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module 2	V	V									V									V	V																																		
R	2014	ELR	Powertrain	Drive Motor Control Module 1		V																			V																																			
R	2014	ELR	Powertrain	Drive Motor Control Module 2		V																			V																																			
R	2014	ELR	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																			
R	2014	ELR	Chassis	Electronic Brake Control Module	V	V																		V	V																													V						
R	2014	ELR	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
R	2014	ELR	Chassis	Parking Brake Control Module	V	V																			V																							V								V	V	V	V		
R	2014	ELR	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
R	2014	ELR	Chassis	Power Steering Control Module	V	V																			V																																			
R	2014	ELR	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
R	2014	ELR	Chassis	Suspension Control Module	V	V																		V	V																																			
R	2014	ELR	Body	Body Control Module	V	V																		V	V																																			
R	2014	ELR	Body	Pedestrian Impact Detection Module	V	V																			V																																			
R	2014	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2014	ELR	Body	Passenger Presence Module	V	V																			V																																			
R	2014	ELR	Body	Instrument Cluster	V	V																		V	V																																			
R	2014	ELR	Body	Radio/HVAC Control	V																																																						
R	2014	ELR	Body	Radio	V	V																		V	V																																			
R	2014	ELR	Body	Amplifier	V	V																			V																																			
R	2014	ELR	Body	Human Machine Interface Control Module	V	V																		V	V																						V													
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
R	2014	ELR	Body	HVAC Control Module	V	V																		V	V																																			
R	2014	ELR	Body	Electric A/C Compressor Control Module																					V																																			
R	2014	ELR	Body	Coolant Heater Control Module	V																				V																																			
R	2014	ELR	Body	Seat Memory Control Module - Driver	V																																																						
R	2014	ELR	Body	Keyless Entry Control Module	V	V																		V	V																																			
R	2014	ELR	Body	Right Side Object Detection Control Module	V																			V	V																																			
R	2014	ELR	Body	Left Side Object Detection Control Module	V																			V	V																																			
R	2014	ELR	Body	Parking Assist Control Module	V	V																		V	V																																			
R	2014	ELR	Body	Frontview Camera Module	V	V																			V																																			
R	2014	ELR	Body	Steering Column Lock Control Module	V	V																			V																																			
R	2014	ELR	Body	Battery Charger Control Module		V																			V																																			
R	2014	ELR	Body	Battery Energy Control Module		V																			V																																			
R	2015	ELR	Powertrain	Engine Control Module	V																			V	V	V	V	V	V	V	V	V																													
R	2015	ELR	Powertrain	Trasmission Control Module	V	V																		V	V										V		V	V									V												
R	2015	ELR	Powertrain	Chassis Control Module	V	V									V									V	V							V																											
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module	V	V	V																	V	V										V																							
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module 2	V	V									V									V	V																																		
R	2015	ELR	Powertrain	Drive Motor Control Module 1		V																			V																																			
R	2015	ELR	Powertrain	Drive Motor Control Module 2		V																			V																																			
R	2015	ELR	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																			
R	2015	ELR	Chassis	Electronic Brake Control Module	V	V																		V	V																													V						
R	2015	ELR	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
R	2015	ELR	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
R	2015	ELR	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
R	2015	ELR	Chassis	Power Steering Control Module	V	V																			V																																			
R	2015	ELR	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
R	2015	ELR	Chassis	Suspension Control Module	V	V																		V	V																																			
R	2015	ELR	Body	Body Control Module	V	V																		V	V																																			
R	2015	ELR	Body	Pedestrian Impact Detection Module	V	V																			V																																			
R	2015	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
R	2015	ELR	Body	Passenger Presence Module	V	V																			V																																			
R	2015	ELR	Body	Instrument Cluster	V	V																		V	V																																			
R	2015	ELR	Body	Radio/HVAC Control	V																				V																																			
R	2015	ELR	Body	Headlamp Control Module	V	V																		V	V																						V													
R	2015	ELR	Body	Radio	V	V																		V	V																																			
R	2015	ELR	Body	Amplifier	V	V																			V																																			
R	2015	ELR	Body	Human Machine Interface Control Module	V	V																		V	V																						V													
R	2015	ELR	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
R	2015	ELR	Body	HVAC Control Module	V	V																		V	V																																			
R	2015	ELR	Body	Electric A/C Compressor Control Module																					V																																			
R	2015	ELR	Body	Coolant Heater Control Module	V																				V																																			
R	2015	ELR	Body	Seat Memory Control Module - Driver	V																																																						
R	2015	ELR	Body	Keyless Entry Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2015	ELR	Body	Right Side Object Detection Control Module	V																		V	V																																				
R	2015	ELR	Body	Left Side Object Detection Control Module	V																		V	V																																				
R	2015	ELR	Body	Parking Assist Control Module	V	V																	V	V																																				
R	2015	ELR	Body	Frontview Camera Module	V	V																		V																																				
R	2015	ELR	Body	Steering Column Lock Control Module	V	V																		V																																				
R	2015	ELR	Body	Battery Charger Control Module		V																		V																																				
R	2015	ELR	Body	Battery Energy Control Module		V																		V																																				
R	2016	ELR	Powertrain	Engine Control Module	V																		V	V	V	V	V	V	V	V	V																													
R	2016	ELR	Powertrain	Trasmission Control Module	V	V																	V	V										V		V	V								V													
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module	V	V	V																V	V										V																								
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module 2	V	V								V									V	V																																			
R	2016	ELR	Powertrain	Drive Motor Control Module 1		V																		V																																			
R	2016	ELR	Powertrain	Drive Motor Control Module 2		V																		V																																			
R	2016	ELR	Powertrain	Auxiliary Transmission Fluid Pump		V																		V																																			
R	2016	ELR	Chassis	Electronic Brake Control Module	V	V																	V	V																														V					
R	2016	ELR	Chassis	Distance Sensing Cruise Control Module	V	V																		V																																			
R	2016	ELR	Chassis	Parking Brake Control Module	V	V																		V																							V						V	V	V	V		
R	2016	ELR	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																			
R	2016	ELR	Chassis	Power Steering Control Module	V	V																		V																																			
R	2016	ELR	Chassis	Steering Wheel Angle Sensor Module	V																			V																																			
R	2016	ELR	Chassis	Suspension Control Module	V	V																	V	V																																			
R	2016	ELR	Body	Body Control Module	V	V																	V	V																																			
R	2016	ELR	Body	Pedestrian Impact Detection Module	V	V																		V																																			
R	2016	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																			
R	2016	ELR	Body	Passenger Presence Module	V	V																		V																																			
R	2016	ELR	Body	Instrument Cluster	V	V																	V	V																																			
R	2016	ELR	Body	Radio/HVAC Control	V																			V																																			
R	2016	ELR	Body	Headlamp Control Module	V	V																	V	V																							V											
R	2016	ELR	Body	Radio	V	V																	V	V																																			
R	2016	ELR	Body	Amplifier	V	V																		V																																			
R	2016	ELR	Body	Human Machine Interface Control Module	V	V																	V	V																							V											
R	2016	ELR	Body	Telematics Communication Interface Control Module	V	V																	V	V																																			
R	2016	ELR	Body	HVAC Control Module	V	V																	V	V																																			
R	2016	ELR	Body	Electric A/C Compressor Control Module																				V																																			
R	2016	ELR	Body	Coolant Heater Control Module	V																			V																																			
R	2016	ELR	Body	Seat Memory Control Module - Driver	V																																																					
R	2016	ELR	Body	Keyless Entry Control Module	V	V																	V	V																																			
R	2016	ELR	Body	Left Side Object Detection Control Module	V																		V	V																																			
R	2016	ELR	Body	Parking Assist Control Module	V	V																	V	V																																			
R	2016	ELR	Body	Frontview Camera Module	V	V																		V																																			
R	2016	ELR	Body	Steering Column Lock Control Module	V	V																		V																																			
R	2016	ELR	Body	Battery Charger Control Module		V																		V																																			
R	2016	ELR	Body	Battery Energy Control Module		V																		V																																			
Y	2004	ALL	Powertrain	Engine Control Module	V	V			V				V			V	V	V			V	V	V	V							V													V														
Y	2004	ALL	Powertrain	Automatic Transmission	V	V																	V											V	V																							
Y	2004	ALL	Chassis	Electronic Brake Control Module	V	V																		V																																			
Y	2004	ALL	Chassis	Electronic Suspension Control	V	V																	V																																			
Y	2004	ALL	Chassis	Steering Wheel and Column	V	V																																																				
Y	2004	ALL	Body	Amplifier (Bose)	V	V																	V																																			
Y	2004	ALL	Body	Body Control Module	V	V																	V	V																																			
Y	2004	ALL	Body	CD Changer	V																																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Y	2004	ALL	Body	Digital Radio Receiver	V	V																			V																																				
Y	2004	ALL	Body	Distance Sensing Cruise Control	V	V																			V																																				
Y	2004	ALL	Body	Driver Door Module	V	V																		V	V																						V													
Y	2004	ALL	Body	Driver Door Switch	V	V																			V																																			
Y	2004	ALL	Body	Driver Position Module	V	V																		V																																				
Y	2004	ALL	Body	Folding Top Module	V	V																		V																																				
Y	2004	ALL	Body	Head Up Display	V	V																		V	V																																			
Y	2004	ALL	Body	HVAC Control Module	V	V																		V	V																																			
Y	2004	ALL	Body	Instrument Panel Cluster	V	V																		V																																				
Y	2004	ALL	Body	Navigation Radio	V	V																																																					
Y	2004	ALL	Body	Passenger Door Module	V	V																		V	V																						V													
Y	2004	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
Y	2004	ALL	Body	Steering Column Lock Module	V	V																																																					
Y	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
Y	2005	ALL	Powertrain	Engine Control Module	V	V			V				V			V	V	V			V	V		V	V							V														V													
Y	2005	ALL	Powertrain	Automatic Transmission	V	V																		V											V	V																							
Y	2005	ALL	Chassis	Electronic Brake Control Module	V	V																			V																																			
Y	2005	ALL	Chassis	Electronic Suspension Control	V	V																		V																																			
Y	2005	ALL	Chassis	Steering Wheel and Column	V	V																																																					
Y	2005	ALL	Body	Amplifier (Bose)	V	V																		V																																			
Y	2005	ALL	Body	Body Control Module	V	V																		V	V																																			
Y	2005	ALL	Body	CD Changer	V																																																					
Y	2005	ALL	Body	Digital Radio Receiver	V	V																			V																																			
Y	2005	ALL	Body	Distance Sensing Cruise Control	V	V																			V																																			
Y	2005	ALL	Body	Driver Door Module	V	V																		V	V																						V													
Y	2005	ALL	Body	Driver Door Switch	V	V																			V																																			
Y	2005	ALL	Body	Driver Position Module	V	V																		V																																				
Y	2005	ALL	Body	Folding Top Module	V	V																		V																																				
Y	2005	ALL	Body	Head Up Display	V	V																		V	V																																			
Y	2005	ALL	Body	HVAC Control Module	V	V																		V	V																																			
Y	2005	ALL	Body	Instrument Panel Cluster	V	V																		V																																				
Y	2005	ALL	Body	Navigation Radio	V	V																																																					
Y	2005	ALL	Body	Passenger Door Module	V	V																		V	V																						V													
Y	2005	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
Y	2005	ALL	Body	Steering Column Lock Module	V	V																																																					
Y	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
Y	2006	(YV)XLR	Powertrain	Engine Control Module	V	V			V				V			V	V	V			V	V		V	V							V														V													
Y	2006	(YV)XLR	Powertrain	Exhaust Flow Control Module	V	V																		V	V																																			
Y	2006	(YV)XLR	Powertrain	Automatic Transmission	V	V																		V											V	V																							
Y	2006	(YV)XLR	Chassis	Electronic Brake Control Module	V	V																			V																																			
Y	2006	(YV)XLR	Chassis	Electronic Suspension Control	V	V																		V																																			
Y	2006	(YV)XLR	Chassis	Steering Wheel and Column	V	V																																																					
Y	2006	(YV)XLR	Body	Amplifier (Bose)	V	V																		V																																			
Y	2006	(YV)XLR	Body	Body Control Module	V	V																		V	V																																			
Y	2006	(YV)XLR	Body	CD Changer	V																																																					
Y	2006	(YV)XLR	Body	Digital Radio Receiver	V	V																			V																																			
Y	2006	(YV)XLR	Body	Distance Sensing Cruise Control	V	V																			V																																			
Y	2006	(YV)XLR	Body	Driver Door Module	V	V																		V	V																						V													
Y	2006	(YV)XLR	Body	Driver Door Switch	V	V																			V																																			
Y	2006	(YV)XLR	Body	Driver Position Module	V	V																		V																																				
Y	2006	(YV)XLR	Body	Folding Top Module	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Y	2006	(YV)XLR	Body	Headlamp Control Module	V	V																		V	V																																			
Y	2006	(YV)XLR	Body	Head Up Display	V	V																		V	V																																			
Y	2006	(YV)XLR	Body	HVAC Control Module	V	V																		V	V																																			
Y	2006	(YV)XLR	Body	Instrument Panel Cluster	V	V																		V																																				
Y	2006	(YV)XLR	Body	Navigation Radio	V	V																																																						
Y	2006	(YV)XLR	Body	Passenger Door Module	V	V																		V	V																						V													
Y	2006	(YV)XLR	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
Y	2006	(YV)XLR	Body	Steering Column Lock Module	V	V																																																						
Y	2006	(YV)XLR	Body	Supplemental Inflatable Restraint	V	V																																																						
Y	2006	(YX)XLR-V	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V		V													
Y	2006	(YX)XLR-V	Powertrain	Exhaust Flow Control Module	V	V																		V	V																																			
Y	2006	(YX)XLR-V	Powertrain	Automatic Transmission	V	V																		V											V	V	V																							
Y	2006	(YX)XLR-V	Chassis	Electronic Brake Control Module	V	V																			V																																			
Y	2006	(YX)XLR-V	Chassis	Electronic Suspension Control	V	V																		V																																			
Y	2006	(YX)XLR-V	Chassis	Steering Wheel and Column	V	V																																																					
Y	2006	(YX)XLR-V	Body	Amplifier (Bose)	V	V																		V																																			
Y	2006	(YX)XLR-V	Body	Body Control Module	V	V																		V	V																																			
Y	2006	(YX)XLR-V	Body	CD Changer	V																																																						
Y	2006	(YX)XLR-V	Body	Digital Radio Receiver	V	V																			V																																			
Y	2006	(YX)XLR-V	Body	Distance Sensing Cruise Control	V	V																			V																																			
Y	2006	(YX)XLR-V	Body	Driver Door Module	V	V																		V	V																						V													
Y	2006	(YX)XLR-V	Body	Driver Door Switch	V	V																			V																																			
Y	2006	(YX)XLR-V	Body	Driver Position Module	V	V																		V																																				
Y	2006	(YX)XLR-V	Body	Folding Top Module	V	V																		V																																				
Y	2006	(YX)XLR-V	Body	Headlamp Control Module	V	V																		V	V																																			
Y	2006	(YX)XLR-V	Body	Head Up Display	V	V																		V	V																																			
Y	2006	(YX)XLR-V	Body	HVAC Control Module	V	V																		V	V																																			
Y	2006	(YX)XLR-V	Body	Instrument Panel Cluster	V	V																		V																																				
Y	2006	(YX)XLR-V	Body	Navigation Radio	V	V																																																						
Y	2006	(YX)XLR-V	Body	Passenger Door Module	V	V																		V	V																						V													
Y	2006	(YX)XLR-V	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
Y	2006	(YX)XLR-V	Body	Steering Column Lock Module	V	V																																																						
Y	2006	(YX)XLR-V	Body	Supplemental Inflatable Restraint	V	V																																																						
Y	2007	(YV)XLR	Powertrain	Engine Control Module	V	V	V		V				V				V	V	V		V	V		V	V							V								V	V	V	V		V													
Y	2007	(YV)XLR	Powertrain	Exhaust Flow Control Module	V	V																		V	V																																			
Y	2007	(YV)XLR	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
Y	2007	(YV)XLR	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
Y	2007	(YV)XLR	Chassis	Electronic Suspension Control	V	V																		V	V																																			
Y	2007	(YV)XLR	Body	Amplifier (Bose)	V	V																		V																																				
Y	2007	(YV)XLR	Body	Body Control Module	V	V																		V	V																																			
Y	2007	(YV)XLR	Body	CD Changer	V																																																						
Y	2007	(YV)XLR	Body	Digital Radio Receiver	V	V																			V																																			
Y	2007	(YV)XLR	Body	Distance Sensing Cruise Control	V	V																			V																																			
Y	2007	(YV)XLR	Body	Driver Door Module	V	V																		V	V																						V													
Y	2007	(YV)XLR	Body	Driver Door Switch	V	V																			V																																			
Y	2007	(YV)XLR	Body	Driver Position Module	V	V																		V																																				
Y	2007	(YV)XLR	Body	Folding Top Module	V	V																		V																																				
Y	2007	(YV)XLR	Body	Headlamp Control Module	V	V																		V	V																																			
Y	2007	(YV)XLR	Body	Head Up Display	V	V																		V	V																																			
Y	2007	(YV)XLR	Body	HVAC Control Module	V	V																		V	V																																			
Y	2007	(YV)XLR	Body	Instrument Panel Cluster	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Right Front Solenoid Valves	ABS Left Front Solenoid Valves	ABS Right Rear Solenoid Valves	ABS Left Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Y	2007	(YV)XLR	Body	Navigation Radio	V	V																																																								
Y	2007	(YV)XLR	Body	Passenger Door Module	V	V																		V	V																					V														
Y	2007	(YV)XLR	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
Y	2007	(YV)XLR	Body	Steering Column Lock Module	V	V																																																						
Y	2007	(YV)XLR	Body	Supplemental Inflatable Restraint	V	V																																																						
Y	2007	(YX)XLR-V	Powertrain	Engine Control Module	V	V	V		V				V				V	V	V		V	V		V	V							V								V	V	V	V		V													
Y	2007	(YX)XLR-V	Powertrain	Exhaust Flow Control Module	V	V																		V	V																																			
Y	2007	(YX)XLR-V	Powertrain	Transmission Control Module	V	V																		V											V	V	V																						
Y	2007	(YX)XLR-V	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
Y	2007	(YX)XLR-V	Chassis	Electronic Suspension Control	V	V																		V	V																																		
Y	2007	(YX)XLR-V	Body	Amplifier (Bose)	V	V																		V																																			
Y	2007	(YX)XLR-V	Body	Body Control Module	V	V																		V	V																																		
Y	2007	(YX)XLR-V	Body	CD Changer	V																																																						
Y	2007	(YX)XLR-V	Body	Digital Radio Receiver	V	V																			V																																		
Y	2007	(YX)XLR-V	Body	Distance Sensing Cruise Control	V	V																			V																																		
Y	2007	(YX)XLR-V	Body	Driver Door Module	V	V																		V	V																					V													
Y	2007	(YX)XLR-V	Body	Driver Door Switch	V	V																			V																																		
Y	2007	(YX)XLR-V	Body	Driver Position Module	V	V																		V																																			
Y	2007	(YX)XLR-V	Body	Folding Top Module	V	V																		V																																			
Y	2007	(YX)XLR-V	Body	Headlamp Control Module	V	V																		V	V																																		
Y	2007	(YX)XLR-V	Body	Head Up Display	V	V																		V	V																																		
Y	2007	(YX)XLR-V	Body	HVAC Control Module	V	V																		V	V																																		
Y	2007	(YX)XLR-V	Body	Instrument Panel Cluster	V	V																		V																																			
Y	2007	(YX)XLR-V	Body	Navigation Radio	V	V																																																						
Y	2007	(YX)XLR-V	Body	Passenger Door Module	V	V																		V	V																					V													
Y	2007	(YX)XLR-V	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
Y	2007	(YX)XLR-V	Body	Steering Column Lock Module	V	V																																																					
Y	2007	(YX)XLR-V	Body	Supplemental Inflatable Restraint	V	V																																																					
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V		V													
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module	V	V																		V	V																																		
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module	V	V																		V											V	V	V																						
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V		V													
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V											V	V	V																						
Y	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
Y	2008	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																		
Y	2008	ALL	Body	Amplifier (Bose)	V	V																		V																																			
Y	2008	ALL	Body	Body Control Module	V	V																		V	V																																		
Y	2008	ALL	Body	CD Changer	V																																																					
Y	2008	ALL	Body	Digital Radio Receiver	V	V																			V																																		
Y	2008	ALL	Body	Distance Sensing Cruise Control	V	V																			V																																		
Y	2008	ALL	Body	Driver Door Module	V	V																		V	V																					V													
Y	2008	ALL	Body	Driver Door Switch	V	V																			V																																		
Y	2008	ALL	Body	Driver Position Module	V	V																		V																																			
Y	2008	ALL	Body	Folding Top Module	V	V																		V																																			
Y	2008	ALL	Body	Headlamp Control Module	V	V																		V	V																																		
Y	2008	ALL	Body	Head Up Display	V	V																		V	V																																		
Y	2008	ALL	Body	HVAC Control Module	V	V																		V	V																																		
Y	2008	ALL	Body	Instrument Panel Cluster	V	V																		V																																			
Y	2008	ALL	Body	Navigation Radio	V	V																																																				
Y	2008	ALL	Body	Passenger Door Module	V	V																		V	V																					V													
Y	2008	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Y	2008	ALL	Body	Steering Column Lock Module	V	V																																																					
Y	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
Y	2008	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V		V												
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module	V	V																		V	V																																	
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module	V	V																		V											V	V	V																					
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V		V												
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V											V	V	V																					
Y	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																	
Y	2009	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																	
Y	2009	ALL	Body	Amplifier (Bose)	V	V																		V																																		
Y	2009	ALL	Body	Body Control Module	V	V																		V	V																																	
Y	2009	ALL	Body	CD Changer	V																																																					
Y	2009	ALL	Body	Digital Radio Receiver	V	V																			V																																	
Y	2009	ALL	Body	Distance Sensing Cruise Control	V	V																			V																																	
Y	2009	ALL	Body	Driver Door Module	V	V																		V	V																						V											
Y	2009	ALL	Body	Driver Door Switch	V	V																			V																																	
Y	2009	ALL	Body	Driver Position Module	V	V																		V																																	
Y	2009	ALL	Body	Folding Top Module	V	V																		V																																	
Y	2009	ALL	Body	Headlamp Control Module	V	V																		V	V																																	
Y	2009	ALL	Body	Head Up Display	V	V																		V	V																																	
Y	2009	ALL	Body	HVAC Control Module	V	V																		V	V																																	
Y	2009	ALL	Body	Instrument Panel Cluster	V	V																		V																																	
Y	2009	ALL	Body	Navigation Radio	V	V																																																			
Y	2009	ALL	Body	Passenger Door Module	V	V																		V	V																						V											
Y	2009	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
Y	2009	ALL	Body	Steering Column Lock Module	V	V																																																				
Y	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
1	2013	XTS	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V			V	V	V	V	V								V	V	V	V	V	V													
1	2013	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V											
1	2013	XTS	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																								
1	2013	XTS	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V											
1	2013	XTS	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
1	2013	XTS	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
1	2013	XTS	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	
1	2013	XTS	Chassis	Power Steering Control Module	V																																																				
1	2013	XTS	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
1	2013	XTS	Chassis	Suspension Control Module	V	V																		V	V																																	
1	2013	XTS	Body	Body Control Module	V	V																		V	V																																	
1	2013	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
1	2013	XTS	Body	Passenger Presence Module	V	V																			V																																	
1	2013	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																		V	V																																	
1	2013	XTS	Body	Instrument Cluster Full Screen Display (UDV)	V	V																		V	V																																	
1	2013	XTS	Body	Radio/HVAC Control	V																																																				
1	2013	XTS	Body	Active Safety Control Module	V	V																		V	V																						V											
1	2013	XTS	Body	Headlamp Control Module	V	V																		V	V																						V											
1	2013	XTS	Body	Radio	V	V																		V	V																																	
1	2013	XTS	Body	Amplifier	V	V																			V																																	
1	2013	XTS	Body	Human Machine Interface Control Module	V	V																		V	V																						V											
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2013	XTS	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
1	2013	XTS	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																			
1	2013	XTS	Body	Seat Memory Control Module	V																																																							
1	2013	XTS	Body	Keyless Entry Control Module	V	V																		V	V																																			
1	2013	XTS	Body	Right Side Object Detection Control Module	V																			V	V																																			
1	2013	XTS	Body	Left Side Object Detection Control Module	V																			V	V																																			
1	2013	XTS	Body	Parking Assist Control Module	V	V																		V	V																																			
1	2013	XTS	Body	Frontview Camera Module	V	V																		V	V																																			
1	2013	XTS	Body	Long Range Radar Sensor Module	V	V																			V																																			
1	2013	XTS	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
1	2013	XTS	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
1	2013	XTS	Body	Rear Short Range Radar Sensor Module	V																				V																																			
1	2014	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V													
1	2014	XTS	Powertrain	(8) 3.6L LF3 Chassis Control Module	V	V																		V	V							V		V																										
1	2014	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
1	2014	XTS	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
1	2014	XTS	Powertrain	(3) 3.6L LFX Chassis Control Module	V	V																		V	V							V		V																										
1	2014	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V												
1	2014	XTS	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																							V											
1	2014	XTS	Chassis	Electronic Brake Control Module	V	V																		V	V													V											V	V	V	V	V	V						V
1	2014	XTS	Chassis	Parking Brake Control Module	V	V																			V																						V						V	V	V	V			
1	2014	XTS	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
1	2014	XTS	Chassis	Power Steering Control Module	V																																																						
1	2014	XTS	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
1	2014	XTS	Chassis	Suspension Control Module	V	V																		V	V																																			
1	2014	XTS	Body	Body Control Module	V	V																		V	V																																			
1	2014	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
1	2014	XTS	Body	Passenger Presence Module	V	V																			V																																			
1	2014	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																		V	V																																			
1	2014	XTS	Body	Instrument Cluster Full Screen Display (UDV)	V	V																		V	V																																			
1	2014	XTS	Body	Radio/HVAC Control	V																																																						
1	2014	XTS	Body	Active Safety Control Module	V	V																		V	V																							V												
1	2014	XTS	Body	Headlamp Control Module	V	V																		V	V																							V												
1	2014	XTS	Body	Radio	V	V																		V	V																																			
1	2014	XTS	Body	Amplifier	V	V																			V																																			
1	2014	XTS	Body	Media Disc Player	V	V																		V	V																																			
1	2014	XTS	Body	Human Machine Interface Control Module	V	V																		V	V																							V												
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
1	2014	XTS	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
1	2014	XTS	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																			
1	2014	XTS	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
1	2014	XTS	Body	Seat Memory Control Module - Driver	V																																																						
1	2014	XTS	Body	Keyless Entry Control Module	V	V																		V	V																																			
1	2014	XTS	Body	Right Side Object Detection Control Module	V																			V	V																																			
1	2014	XTS	Body	Left Side Object Detection Control Module	V																			V	V																																			
1	2014	XTS	Body	Parking Assist Control Module	V																			V	V																																			
1	2014	XTS	Body	Frontview Camera Module	V	V																		V	V																																			
1	2014	XTS	Body	Long Range Radar Sensor Module	V	V																			V																																			
1	2014	XTS	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
1	2014	XTS	Body	Right Front Short Range Radar Sensor Module	V																				V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2014	XTS	Body	Rear Short Range Radar Sensor Module	V																			V																																			
1	2015	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module	V																		V	V				V	V	V	V	V								V	V	V	V		V													
1	2015	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module	V	V																	V	V									V	V	V	V									V													
1	2015	XTS	Powertrain	(3) 3.6L LFX Engine Control Module	V																		V	V				V	V	V	V	V								V	V	V	V	V	V													
1	2015	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																	V	V									V	V	V	V									V													
1	2015	XTS	Powertrain	Chassis Control Module	V	V																	V	V							V		V																									
1	2015	XTS	Powertrain	Rear Differential Clutch Control Module	V	V																	V	V																						V												
1	2015	XTS	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V						V
1	2015	XTS	Chassis	Parking Brake Control Module	V	V																		V																					V							V	V	V	V		
1	2015	XTS	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																	
1	2015	XTS	Chassis	Power Steering Control Module	V																																																				
1	2015	XTS	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
1	2015	XTS	Chassis	Suspension Control Module	V	V																	V	V																																		
1	2015	XTS	Body	Body Control Module	V	V																	V	V																																		
1	2015	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
1	2015	XTS	Body	Passenger Presence Module	V	V																		V																																		
1	2015	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																	V	V																																		
1	2015	XTS	Body	Instrument Cluster Full Screen Display (UDV)	V	V																	V	V																																		
1	2015	XTS	Body	Radio/HVAC Control	V																			V																																		
1	2015	XTS	Body	Active Safety Control Module	V	V																	V	V																						V												
1	2015	XTS	Body	Radio	V	V																	V	V																																		
1	2015	XTS	Body	Amplifier	V	V																		V																																		
1	2015	XTS	Body	Media Disc Player	V	V																	V	V																																		
1	2015	XTS	Body	Human Machine Interface Control Module	V	V																	V	V																						V												
1	2015	XTS	Body	Telematics Communication Interface Control Module	V	V																	V	V																																		
1	2015	XTS	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																	V	V																																		
1	2015	XTS	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																	V	V																																		
1	2015	XTS	Body	Seat Memory Control Module - Passenger	V	V																	V	V																																		
1	2015	XTS	Body	Seat Memory Control Module - Driver	V																																																				
1	2015	XTS	Body	Keyless Entry Control Module	V	V																	V	V																																		
1	2015	XTS	Body	Right Side Object Detection Control Module	V																		V	V																																		
1	2015	XTS	Body	Left Side Object Detection Control Module	V																		V	V																																		
1	2015	XTS	Body	Parking Assist Control Module GMLAN	V	V																	V	V																																		
1	2015	XTS	Body	Parking Assist Control Module DID72History	V																		V	V																																		
1	2015	XTS	Body	Frontview Camera Module	V	V																	V	V																																		
1	2015	XTS	Body	Long Range Radar Sensor Module	V	V																		V																																		
1	2015	XTS	Body	Left Front Short Range Radar Sensor Module	V																			V																																		
1	2015	XTS	Body	Right Front Short Range Radar Sensor Module	V																			V																																		
1	2015	XTS	Body	Rear Short Range Radar Sensor Module	V																			V																																		
1	2016	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module	V																		V	V				V	V	V	V	V												V														
1	2016	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module	V	V																	V	V									V	V	V	V									V													
1	2016	XTS	Powertrain	(3) 3.6L LFX Engine Control Module	V																		V	V				V	V	V	V	V								V	V	V	V	V	V													
1	2016	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																	V	V									V	V	V	V									V													
1	2016	XTS	Powertrain	Chassis Control Module	V	V																	V	V							V		V																									
1	2016	XTS	Powertrain	Rear Differential Clutch Control Module	V	V																	V	V																						V												
1	2016	XTS	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V						V
1	2016	XTS	Chassis	Parking Brake Control Module	V	V																		V																						V							V	V	V	V		
1	2016	XTS	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																		
1	2016	XTS	Chassis	Power Steering Control Module	V																																																				
1	2016	XTS	Chassis	Steering Wheel Angle Sensor Module	V																			V																																		
1	2016	XTS	Chassis	Suspension Control Module	V	V																	V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2016	XTS	Body	Body Control Module	V	V																		V	V																																			
1	2016	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
1	2016	XTS	Body	Passenger Presence Module	V	V																			V																																			
1	2016	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																		V	V																																			
1	2016	XTS	Body	Instrument Cluster Full Screen Display (UDV)	V	V																		V	V																																			
1	2016	XTS	Body	Radio/HVAC Control	V																				V																																			
1	2016	XTS	Body	Active Safety Control Module	V	V																		V	V																							V											
1	2016	XTS	Body	Video Processing Control Module	V	V																		V	V																																			
1	2016	XTS	Body	Radio	V	V																		V	V																																			
1	2016	XTS	Body	Amplifier	V	V																			V																																			
1	2016	XTS	Body	Media Disc Player	V	V																		V	V																																			
1	2016	XTS	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
1	2016	XTS	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
1	2016	XTS	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
1	2016	XTS	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																			
1	2016	XTS	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
1	2016	XTS	Body	Seat Memory Control Module - Driver	V																																																							
1	2016	XTS	Body	Keyless Entry Control Module	V	V																		V	V																																			
1	2016	XTS	Body	Right Side Object Detection Control Module	V																			V	V																																			
1	2016	XTS	Body	Left Side Object Detection Control Module	V																			V	V																																			
1	2016	XTS	Body	Parking Assist Control Module	V																			V	V																																			
1	2016	XTS	Body	Frontview Camera Module	V	V																		V	V																																			
1	2016	XTS	Body	Steering Column Lock Control Module	V	V																			V																																			
1	2016	XTS	Body	Long Range Radar Sensor Module	V	V																			V																																			
1	2016	XTS	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
1	2016	XTS	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
1	2016	XTS	Body	Rear Short Range Radar Sensor Module	V																				V																																			

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																				V																																					
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																				V																																					
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump																																																									
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																									
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Engine Mount																																																								
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																								
A	2013	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
A	2013	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																				V																																				
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump																																																								
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																								
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Engine Mount																																																								
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																								
A	2013	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																					
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump																																																								
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																								
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Engine Mount																																																								
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																								
A	2013	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
A	2013	ATS	Powertrain	Transfer Case Control Module																																																								
A	2013	ATS	Chassis	Electronic Brake Control Module					V																																																		
A	2013	ATS	Chassis	Parking Brake Control Module																																																							
A	2013	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																							
A	2013	ATS	Chassis	Power Steering Control Module																																																							
A	2013	ATS	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
A	2013	ATS	Chassis	Suspension Control Module																																																							
A	2013	ATS	Body	Body Control Module Halogen						V	V	V	V	V	V	V	V		V		V	V	V	V	V	V	V	V																								V						
A	2013	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V		V		V	V	V	V	V	V	V	V																								V						
A	2013	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
A	2013	ATS	Body	Passenger Presence Module																																V																							
A	2013	ATS	Body	Pedestrian Impact Detection Module																																																							
A	2013	ATS	Body	Instrument Cluster																																	V																					
A	2013	ATS	Body	Radio/HVAC Control																																																						
A	2013	ATS	Body	Active Safety Control Module																																																						
A	2013	ATS	Body	Headlamp Control Module																																																						
A	2013	ATS	Body	Trailer Interface Control Module																																	V																					
A	2013	ATS	Body	Radio																																																						
A	2013	ATS	Body	Amplifier																																																						
A	2013	ATS	Body	Human Machine Interface Control Module																																																						
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																		
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
A	2013	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V		V							
A	2013	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																														V												V	V		V							
A	2013	ATS	Body	Seat Memory Control Module																																																						
A	2013	ATS	Body	Keyless Entry Type Without Passive Entry																																																						
A	2013	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																						
A	2013	ATS	Body	Right Side Object Detection Control Module																																																						
A	2013	ATS	Body	Left Side Object Detection Control Module																																																						
A	2013	ATS	Body	Parking Assist Control Module																																	V																					
A	2013	ATS	Body	Frontview Camera Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2013	ATS	Body	Steering Column Lock Control Module																																																											
A	2013	ATS	Body	Long Range Radar Sensor Module																																																											
A	2013	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2013	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2013	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Engine Control Module																				V																																						
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																					V	V		
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																									
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																					V	V		
A	2014	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																				V																																						
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																					V	V		
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																					V	V		
A	2014	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																							
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																					V	V		
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																					V	V		
A	2014	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2014	ATS	Powertrain	Transfer Case Control Module																																																											
A	2014	ATS	Chassis	Electronic Brake Control Module					V																																																						
A	2014	ATS	Chassis	Parking Brake Control Module																																																											
A	2014	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2014	ATS	Chassis	Power Steering Control Module																																																											
A	2014	ATS	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
A	2014	ATS	Chassis	Suspension Control Module																																																											
A	2014	ATS	Body	Body Control Module Halogen						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V	V																								V								
A	2014	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V	V																								V								
A	2014	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																									
A	2014	ATS	Body	Passenger Presence Module																																V																											
A	2014	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2014	ATS	Body	Instrument Cluster																																	V																									
A	2014	ATS	Body	Radio/HVAC Control																																																										
A	2014	ATS	Body	Active Safety Control Module																																																										
A	2014	ATS	Body	Headlamp Control Module																																																										
A	2014	ATS	Body	Trailer Interface Control Module																																	V																									
A	2014	ATS	Body	Radio																																																										
A	2014	ATS	Body	Amplifier																																																										
A	2014	ATS	Body	Media Disc Player																																																										
A	2014	ATS	Body	Human Machine Interface Control Module																																																										
A	2014	ATS	Body	Navigation Control Module																																																										
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																					
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
A	2014	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V		V									
A	2014	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																														V												V	V		V									
A	2014	ATS	Body	Seat Memory Control Module - Driver																																																										
A	2014	ATS	Body	Keyless Entry Type Without Passive Entry																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2014	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
A	2014	ATS	Body	Right Side Object Detection Control Module																																																										
A	2014	ATS	Body	Left Side Object Detection Control Module																																																										
A	2014	ATS	Body	Parking Assist Control Module																																V																										
A	2014	ATS	Body	Frontview Camera Module																																																										
A	2014	ATS	Body	Steering Column Lock Control Module																																																										
A	2014	ATS	Body	Long Range Radar Sensor Module																																																										
A	2014	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2014	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2014	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																				V																																					
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Maunal Transmission																				V																																					
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																						V	V		
A	2014	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2014	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																				V																																						
A	2014	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																										
A	2014	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																					V				
A	2014	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																						
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																					V				
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																						V	V		
A	2014	CTS	Powertrain	Transfer Case Control Module																																																										
A	2014	CTS	Chassis	Electronic Brake Control Module					V																																																					
A	2014	CTS	Chassis	Parking Brake Control Module																																																										
A	2014	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	CTS	Chassis	Power Steering Control Module																																																										
A	2014	CTS	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
A	2014	CTS	Chassis	Suspension Control Module																																																										
A	2014	CTS	Body	Body Control Module Headlamp Type Halogen						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																												V				
A	2014	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																												V				
A	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
A	2014	CTS	Body	Passenger Presence Module																																V																										
A	2014	CTS	Body	Pedestrian Impact Detection Module																																																										
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2014	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																	V																									
A	2014	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																	V																									
A	2014	CTS	Body	Radio/HVAC Control																																																										
A	2014	CTS	Body	Active Safety Control Module																																																										
A	2014	CTS	Body	Headlamp Control Module																																																										
A	2014	CTS	Body	Trailer Interface Control Module																																	V																									
A	2014	CTS	Body	Radio																																																										
A	2014	CTS	Body	Amplifier																																																										
A	2014	CTS	Body	Human Machine Interface Control Module																																																										
A	2014	CTS	Body	Navigation Control Module																																																										
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																					
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2014	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																															V												V	V		V								
A	2014	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																															V												V	V		V								
A	2014	CTS	Body	Seat Memory Control Module - Driver																																																						
A	2014	CTS	Body	Keyless Entry Control Module																																																						
A	2014	CTS	Body	Right Side Object Detection Control Module																																																						
A	2014	CTS	Body	Left Side Object Detection Control Module																																																						
A	2014	CTS	Body	Parking Assist Control Module																																V																							
A	2014	CTS	Body	Frontview Camera Module																																																						
A	2014	CTS	Body	Steering Column Lock Control Module																																																						
A	2014	CTS	Body	Long Range Radar Sensor Module																																																						
A	2014	CTS	Body	Left Front Short Range Radar Sensor Module																																																						
A	2014	CTS	Body	Right Front Short Range Radar Sensor Module																																																						
A	2014	CTS	Body	Rear Short Range Radar Sensor Module																																																						
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																				V																																			
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																				V																																			
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																						
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																			V	V		
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																					
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																			V	V		
A	2015	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																					
A	2015	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																				V																																			
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																						
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																			V	V		
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																					
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																			V	V		
A	2015	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																					
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																			
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																						
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																						
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																			V	V		
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																					
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																			V	V		
A	2015	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																					
A	2015	ATS	Powertrain	Transfer Case Control Module																																																					
A	2015	ATS	Chassis	Electronic Brake Control Module					V																																																
A	2015	ATS	Chassis	Parking Brake Control Module																																																					
A	2015	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																					
A	2015	ATS	Chassis	Power Steering Control Module																																																					
A	2015	ATS	Chassis	Steering Wheel Angle Sensor Module				V	V																																																
A	2015	ATS	Chassis	Suspension Control Module																																																					
A	2015	ATS	Body	Body Control Module Halogen						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																						V							
A	2015	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																						V							
A	2015	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																						
A	2015	ATS	Body	Passenger Presence Module																																V																						
A	2015	ATS	Body	Pedestrian Impact Detection Module																																																					
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Left																																																					
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Right																																																					
A	2015	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																	V																				
A	2015	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																	V																				
A	2015	ATS	Body	Radio/HVAC Control																																																					
A	2015	ATS	Body	Active Safety Control Module																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2015	ATS	Body	Headlamp Control Module																																																								
A	2015	ATS	Body	Trailer Interface Control Module																																V																								
A	2015	ATS	Body	Radio																																																								
A	2015	ATS	Body	Amplifier																																																								
A	2015	ATS	Body	Media Disc Player																																																								
A	2015	ATS	Body	Human Machine Interface Control Module																																																								
A	2015	ATS	Body	Navigation Control Module																																																								
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
A	2015	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V		V								
A	2015	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																														V												V	V		V								
A	2015	ATS	Body	Seat Memory Control Module - Driver																																																								
A	2015	ATS	Body	Keyless Entry Control Module Coupe																																																								
A	2015	ATS	Body	Keyless Entry Control Module Sadan																																																								
A	2015	ATS	Body	Right Side Object Detection Control Module																																																								
A	2015	ATS	Body	Left Side Object Detection Control Module																																																								
A	2015	ATS	Body	Parking Assist Control Module																																V																								
A	2015	ATS	Body	Frontview Camera Module																																																								
A	2015	ATS	Body	Steering Column Lock Control Module																																																								
A	2015	ATS	Body	Long Range Radar Sensor Module																																																								
A	2015	ATS	Body	Left Front Short Range Radar Sensor Module																																																								
A	2015	ATS	Body	Right Front Short Range Radar Sensor Module																																																								
A	2015	ATS	Body	Rear Short Range Radar Sensor Module																																																								
A	2015	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																				V																																				
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Engine Mount																																																								
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																								
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																				V	V		
A	2015	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
A	2015	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																				V																																				
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																								
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Fuel Pump and Engine Mount																																																								
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Active Grile Air Shutter And Engine Mount																																																			V	V		
A	2015	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																			V				
A	2015	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																								
A	2015	CTS	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Engine Mount																																																								
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																								
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																			V	V		
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																								
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																			V				
A	2015	CTS	Powertrain	Transfer Case Control Module																																																								
A	2015	CTS	Chassis	Electronic Brake Control Module					V																																																			
A	2015	CTS	Chassis	Parking Brake Control Module																																																								
A	2015	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2015	CTS	Chassis	Power Steering Control Module																																																								
A	2015	CTS	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
A	2015	CTS	Chassis	Suspension Control Module																																																								
A	2015	CTS	Body	Body Control Module Headlamp Type Halogen						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																									V					
A	2015	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																									V					
A	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
A	2015	CTS	Body	Passenger Presence Module																																V																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2015	CTS	Body	Pedestrian Impact Detection Module																																																								
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Left																																																								
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Right																																																								
A	2015	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																V																							
A	2015	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																V																							
A	2015	CTS	Body	Active Safety Control Module																																																							
A	2015	CTS	Body	Trailer Interface Control Module																																V																							
A	2015	CTS	Body	Radio																																																							
A	2015	CTS	Body	Amplifier																																																						
A	2015	CTS	Body	Human Machine Interface Control Module																																																						
A	2015	CTS	Body	Navigation Control Module																																																						
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																			
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
A	2015	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																														V													V	V		V							
A	2015	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																														V													V	V		V							
A	2015	CTS	Body	Seat Memory Control Module - Driver																																																							
A	2015	CTS	Body	Keyless Entry Control Module																																																							
A	2015	CTS	Body	Right Side Object Detection Control Module																																																							
A	2015	CTS	Body	Left Side Object Detection Control Module																																																							
A	2015	CTS	Body	Parking Assist Control Module																																V																							
A	2015	CTS	Body	Frontview Camera Module																																																							
A	2015	CTS	Body	Steering Column Lock Control Module																																																							
A	2015	CTS	Body	Long Range Radar Sensor Module																																																							
A	2015	CTS	Body	Left Front Short Range Radar Sensor Module																																																							
A	2015	CTS	Body	Right Front Short Range Radar Sensor Module																																																							
A	2015	CTS	Body	Rear Short Range Radar Sensor Module																																																							
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																				V																																				
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																							
A	2016	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																							
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																			
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																							
A	2016	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																							
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Automatic Transmission																				V																																V				
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Manual Transmission																				V																																				
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Transmission Control Module																																																							
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																				V																																				
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																				V																																				
A	2016	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																							
A	2016	ATS	Powertrain	Transfer Case Control Module																																																							
A	2016	ATS	Powertrain	Rear Differential Clutch Control Module																																																							
A	2016	ATS	Chassis	Electronic Brake Control Module					V																																																		
A	2016	ATS	Chassis	Parking Brake Control Module																																																							
A	2016	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																							
A	2016	ATS	Chassis	Power Steering Control Module																																																							
A	2016	ATS	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
A	2016	ATS	Chassis	Suspension Control Module																																																							
A	2016	ATS	Body	Body Control Module Halogen						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																								V						
A	2016	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																								V						
A	2016	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
A	2016	ATS	Body	Passenger Presence Module																																V																							
A	2016	ATS	Body	Pedestrian Impact Detection Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Left																																																								
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Right																																																									
A	2016	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																V																								
A	2016	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																V																								
A	2016	ATS	Body	Radio/HVAC Control																																																								
A	2016	ATS	Body	Vehicle Performance Data Recorder																																																								
A	2016	ATS	Body	Trailer Interface Control Module																																V																								
A	2016	ATS	Body	Radio																																																								
A	2016	ATS	Body	Amplifier																																																								
A	2016	ATS	Body	Rear Audio Control Module																																																								
A	2016	ATS	Body	Media Disc Player																																																								
A	2016	ATS	Body	Human Machine Interface Control Module																																																								
A	2016	ATS	Body	Navigation Control Module																																																								
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
A	2016	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																														V													V	V		V								
A	2016	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																														V													V	V		V								
A	2016	ATS	Body	Seat Memory Control Module - Passenger																																																								
A	2016	ATS	Body	Seat Memory Control Module - Driver																																																								
A	2016	ATS	Body	Keyless Entry Control Module Coupe																																																								
A	2016	ATS	Body	Keyless Entry Control Module Sadan																																																								
A	2016	ATS	Body	Right Side Object Detection Control Module																																																								
A	2016	ATS	Body	Left Side Object Detection Control Module																																																								
A	2016	ATS	Body	Parking Assist Control Module																																V																								
A	2016	ATS	Body	Frontview Camera Module																																																								
A	2016	ATS	Body	Steering Column Lock Control Module																																																								
A	2016	ATS	Body	Long Range Radar Sensor Module																																																								
A	2016	ATS	Body	Left Front Short Range Radar Sensor Module																																																								
A	2016	ATS	Body	Right Front Short Range Radar Sensor Module																																																								
A	2016	ATS	Body	Rear Short Range Radar Sensor Module																																																								
A	2016	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																				V																																				
A	2016	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
A	2016	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																				V																																				
A	2016	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																				V			
A	2016	CTS	Powertrain	(S) 3.6L LGX Engine Control Module																				V																																				
A	2016	CTS	Powertrain	(S) 3.6L LGX Transmission Control Module																																																								
A	2016	CTS	Powertrain	(6) 6.2L LT4 Engine Control Module																				V																																				
A	2016	CTS	Powertrain	(6) 6.2L LT4 Transmission Control Module																																																								
A	2016	CTS	Powertrain	Rear Differential Clutch Control Module																																																								
A	2016	CTS	Powertrain	Transfer Case Control Module																																																								
A	2016	CTS	Chassis	Electronic Brake Control Module					V																																																			
A	2016	CTS	Chassis	Parking Brake Control Module																																																								
A	2016	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2016	CTS	Chassis	Power Steering Control Module																																																								
A	2016	CTS	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
A	2016	CTS	Chassis	Suspension Control Module																																																								
A	2016	CTS	Body	Body Control Module Headlamp Type Halogen						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																									V					
A	2016	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																									V					
A	2016	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
A	2016	CTS	Body	Passenger Presence Module																																V																							
A	2016	CTS	Body	Pedestrian Impact Detection Module																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Left																																																								
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Right																																																									
A	2016	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																V																								
A	2016	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																V																								
A	2016	CTS	Body	Radio/HVAC Control																																																								
A	2016	CTS	Body	Vehicle Performance Data Recorder																																																								
A	2016	CTS	Body	Active Safety Control Module																																																								
A	2016	CTS	Body	Video Processing Control Module																																																								
A	2016	CTS	Body	Trailer Interface Control Module																																V																								
A	2016	CTS	Body	Radio																																																								
A	2016	CTS	Body	Amplifier																																																								
A	2016	CTS	Body	Human Machine Interface Control Module																																																								
A	2016	CTS	Body	Navigation Control Module																																																								
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
A	2016	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																														V													V	V		V								
A	2016	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																														V													V	V		V								
A	2016	CTS	Body	Seat Memory Control Module - Passenger																																																								
A	2016	CTS	Body	Seat Memory Control Module - Driver																																																								
A	2016	CTS	Body	Keyless Entry Control Module																																																								
A	2016	CTS	Body	Right Side Object Detection Control Module																																																								
A	2016	CTS	Body	Left Side Object Detection Control Module																																																								
A	2016	CTS	Body	Parking Assist Control Module																																V																								
A	2016	CTS	Body	Frontview Camera Module																																																								
A	2016	CTS	Body	Steering Column Lock Control Module																																																								
A	2016	CTS	Body	Long Range Radar Sensor Module																																																								
A	2016	CTS	Body	Left Front Short Range Radar Sensor Module																																																								
A	2016	CTS	Body	Right Front Short Range Radar Sensor Module																																																								
A	2016	CTS	Body	Rear Short Range Radar Sensor Module																																																								
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																								
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																								
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																								
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																								
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																								
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																								
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2004	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																								
D	2004	(DM)CTS	Chassis	VES																																																								
D	2004	(DM)CTS	Body	Amplifier (Bose)																																																								
D	2004	(DM)CTS	Body	Amplifier (Delco)																																																								
D	2004	(DM)CTS	Body	Climate Control Panel																																										V														
D	2004	(DM)CTS	Body	Dash Integration Module																																																								
D	2004	(DM)CTS	Body	Digital Radio Receiver																																																								
D	2004	(DM)CTS	Body	Driver Door Switch																																																								
D	2004	(DM)CTS	Body	Driver Door Module																																																								
D	2004	(DM)CTS	Body	Passenger Door Module																																																								
D	2004	(DM)CTS	Body	Left Rear Door Module																																																								
D	2004	(DM)CTS	Body	Right Rear Door Module																																																								
D	2004	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																								
D	2004	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2004	(DM)CTS	Body	Instrument Panel Cluster																																																									
D	2004	(DM)CTS	Body	Memory Seat Module																																																										
D	2004	(DM)CTS	Body	Personalization																																																									
D	2004	(DM)CTS	Body	Rear Integration Module																																																									
D	2004	(DM)CTS	Body	Remote Function Actuation																																																									
D	2004	(DM)CTS	Body	Supplemental Inflatable Restraint																																																									
D	2004	(DM)CTS	Body	TV Antenna Module																																																									
D	2004	(DM)CTS	Body	Vehicle Theft Deterrent																																																									
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																									
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																									
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																									
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																									
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																									
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																									
D	2004	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																									
D	2004	(DR)CTS	Chassis	VES																																																									
D	2004	(DR)CTS	Body	Amplifier (Bose)																																																									
D	2004	(DR)CTS	Body	Amplifier (Delco)																																																									
D	2004	(DR)CTS	Body	Climate Control Panel																																												V													
D	2004	(DR)CTS	Body	Dash Integration Module																																																									
D	2004	(DR)CTS	Body	Digital Radio Receiver																																																									
D	2004	(DR)CTS	Body	Driver Door Switch																																																									
D	2004	(DR)CTS	Body	Driver Door Module																																																									
D	2004	(DR)CTS	Body	Passenger Door Module																																																									
D	2004	(DR)CTS	Body	Left Rear Door Module																																																									
D	2004	(DR)CTS	Body	Right Rear Door Module																																																									
D	2004	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																									
D	2004	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																									
D	2004	(DR)CTS	Body	Instrument Panel Cluster																																																									
D	2004	(DR)CTS	Body	Memory Seat Module																																																									
D	2004	(DR)CTS	Body	Personalization																																																									
D	2004	(DR)CTS	Body	Rear Integration Module																																																									
D	2004	(DR)CTS	Body	Remote Function Actuation																																																									
D	2004	(DR)CTS	Body	Supplemental Inflatable Restraint																																																									
D	2004	(DR)CTS	Body	TV Antenna Module																																																									
D	2004	(DR)CTS	Body	Vehicle Theft Deterrent																																																									
D	2004	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																									
D	2004	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																									
D	2004	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																									
D	2004	(DN)CTS-V	Chassis	VES																																																									
D	2004	(DN)CTS-V	Body	Amplifier (Bose)																																																									
D	2004	(DN)CTS-V	Body	Amplifier (Delco)																																																									
D	2004	(DN)CTS-V	Body	Climate Control Panel																																												V													
D	2004	(DN)CTS-V	Body	Dash Integration Module																																																									
D	2004	(DN)CTS-V	Body	Digital Radio Receiver																																																									
D	2004	(DN)CTS-V	Body	Driver Door Switch																																																									
D	2004	(DN)CTS-V	Body	Driver Door Module																																																									
D	2004	(DN)CTS-V	Body	Passenger Door Module																																																									
D	2004	(DN)CTS-V	Body	Left Rear Door Module																																																									
D	2004	(DN)CTS-V	Body	Right Rear Door Module																																																									
D	2004	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2004	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																								
D	2004	(DN)CTS-V	Body	Instrument Panel Cluster																																																								
D	2004	(DN)CTS-V	Body	Memory Seat Module																																																								
D	2004	(DN)CTS-V	Body	Personalization																																																								
D	2004	(DN)CTS-V	Body	Rear Integration Module																																																								
D	2004	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																								
D	2004	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																								
D	2004	(DN)CTS-V	Body	TV Antenna Module																																																								
D	2004	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																								
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																								
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																								
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2005	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																								
D	2005	(DM)CTS	Chassis	VES																																																								
D	2005	(DM)CTS	Body	Amplifier (Bose)																																																								
D	2005	(DM)CTS	Body	Amplifier (Delco)																																																								
D	2005	(DM)CTS	Body	Climate Control Panel																																												V												
D	2005	(DM)CTS	Body	Dash Integration Module																																																								
D	2005	(DM)CTS	Body	Digital Radio Receiver																																																								
D	2005	(DM)CTS	Body	Driver Door Switch																																																								
D	2005	(DM)CTS	Body	Driver Door Module																																																								
D	2005	(DM)CTS	Body	Passenger Door Module																																																								
D	2005	(DM)CTS	Body	Left Rear Door Module																																																								
D	2005	(DM)CTS	Body	Right Rear Door Module																																																								
D	2005	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																								
D	2005	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																								
D	2005	(DM)CTS	Body	Instrument Panel Cluster																																																								
D	2005	(DM)CTS	Body	Memory Seat Module																																																								
D	2005	(DM)CTS	Body	Personalization																																																								
D	2005	(DM)CTS	Body	Rear Integration Module																																																								
D	2005	(DM)CTS	Body	Remote Control Door Lock Receiver																																																								
D	2005	(DM)CTS	Body	Supplemental Inflatable Restraint																																																								
D	2005	(DM)CTS	Body	TV Antenna Module																																																								
D	2005	(DM)CTS	Body	Vehicle Theft Deterrent																																																								
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																								
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																								
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2005	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																								
D	2005	(DP)CTS	Chassis	VES																																																								
D	2005	(DP)CTS	Body	Amplifier (Bose)																																																								
D	2005	(DP)CTS	Body	Amplifier (Delco)																																																								
D	2005	(DP)CTS	Body	Climate Control Panel																																												V												
D	2005	(DP)CTS	Body	Dash Integration Module																																																								
D	2005	(DP)CTS	Body	Digital Radio Receiver																																																								
D	2005	(DP)CTS	Body	Driver Door Switch																																																								
D	2005	(DP)CTS	Body	Driver Door Module																																																								
D	2005	(DP)CTS	Body	Passenger Door Module																																																								
D	2005	(DP)CTS	Body	Left Rear Door Module																																																								
D	2005	(DP)CTS	Body	Right Rear Door Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2005	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2005	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2005	(DP)CTS	Body	Instrument Panel Cluster																																																												
D	2005	(DP)CTS	Body	Memory Seat Module																																																												
D	2005	(DP)CTS	Body	Personalization																																																												
D	2005	(DP)CTS	Body	Rear Integration Module																																																												
D	2005	(DP)CTS	Body	Remote Control Door Lock Receiver																																																												
D	2005	(DP)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2005	(DP)CTS	Body	TV Antenna Module																																																												
D	2005	(DP)CTS	Body	Vehicle Theft Deterrent																																																												
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																												
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2005	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2005	(DR)CTS	Chassis	VES																																																												
D	2005	(DR)CTS	Body	Amplifier (Bose)																																																												
D	2005	(DR)CTS	Body	Amplifier (Delco)																																																												
D	2005	(DR)CTS	Body	Climate Control Panel																																												V																
D	2005	(DR)CTS	Body	Dash Integration Module																																																											
D	2005	(DR)CTS	Body	Digital Radio Receiver																																																												
D	2005	(DR)CTS	Body	Driver Door Switch																																																												
D	2005	(DR)CTS	Body	Driver Door Module																																																												
D	2005	(DR)CTS	Body	Passenger Door Module																																																												
D	2005	(DR)CTS	Body	Left Rear Door Module																																																												
D	2005	(DR)CTS	Body	Right Rear Door Module																																																												
D	2005	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2005	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2005	(DR)CTS	Body	Instrument Panel Cluster																																																												
D	2005	(DR)CTS	Body	Memory Seat Module																																																												
D	2005	(DR)CTS	Body	Personalization																																																												
D	2005	(DR)CTS	Body	Radio																																																												
D	2005	(DR)CTS	Body	Rear Integration Module																																																												
D	2005	(DR)CTS	Body	Remote Control Door Lock Receiver																																																												
D	2005	(DR)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2005	(DR)CTS	Body	TV Antenna Module																																																												
D	2005	(DR)CTS	Body	Vehicle Theft Deterrent																																																												
D	2005	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																												
D	2005	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																												
D	2005	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																												
D	2005	(DN)CTS-V	Chassis	VES																																																												
D	2005	(DN)CTS-V	Body	Amplifier (Bose)																																																												
D	2005	(DN)CTS-V	Body	Amplifier (Delco)																																																												
D	2005	(DN)CTS-V	Body	Climate Control Panel																																												V																
D	2005	(DN)CTS-V	Body	Dash Integration Module																																																												
D	2005	(DN)CTS-V	Body	Digital Radio Receiver																																																												
D	2005	(DN)CTS-V	Body	Driver Door Switch																																																												
D	2005	(DN)CTS-V	Body	Driver Door Module																																																												
D	2005	(DN)CTS-V	Body	Passenger Door Module																																																												
D	2005	(DN)CTS-V	Body	Left Rear Door Module																																																												
D	2005	(DN)CTS-V	Body	Right Rear Door Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2005	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																												
D	2005	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																													
D	2005	(DN)CTS-V	Body	Instrument Panel Cluster																																																													
D	2005	(DN)CTS-V	Body	Memory Seat Module																																																													
D	2005	(DN)CTS-V	Body	Personalization																																																													
D	2005	(DN)CTS-V	Body	Radio																																																													
D	2005	(DN)CTS-V	Body	Rear Integration Module																																																													
D	2005	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																													
D	2005	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																													
D	2005	(DN)CTS-V	Body	TV Antenna Module																																																													
D	2005	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																													
D	2005	(DC)STS-V8	Powertrain	Engine Control Module																																																													
D	2005	(DC)STS-V8	Powertrain	Transmission Control Module																																																													
D	2005	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																													
D	2005	(DC)STS-V8	Chassis	Electronic Suspension Control																																																													
D	2005	(DC)STS-V8	Body	Amplifier (Bose)																																																												
D	2005	(DC)STS-V8	Body	Digital Radio Receiver																																																												
D	2005	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																												
D	2005	(DC)STS-V8	Body	Driver Door Module																																																												
D	2005	(DC)STS-V8	Body	Driver Door Switch																																																												
D	2005	(DC)STS-V8	Body	Driver Position Module																																																												
D	2005	(DC)STS-V8	Body	Headlamp Control Module																																																												
D	2005	(DC)STS-V8	Body	Head Up Display																																																												
D	2005	(DC)STS-V8	Body	HVAC Control Module																																												V															
D	2005	(DC)STS-V8	Body	Instrument Panel Cluster																																																												
D	2005	(DC)STS-V8	Body	Instrument Panel Module																																																												
D	2005	(DC)STS-V8	Body	Left Rear Door Module																																																												
D	2005	(DC)STS-V8	Body	Passenger Door Module																																																												
D	2005	(DC)STS-V8	Body	Uplevel Radio																																																												
D	2005	(DC)STS-V8	Body	Navigation Radio																																																												
D	2005	(DC)STS-V8	Body	Rear Integration Module																																																												
D	2005	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																												
D	2005	(DC)STS-V8	Body	Right Rear Door Module																																																												
D	2005	(DC)STS-V8	Body	Steering Column Lock Module																																																												
D	2005	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																												
D	2005	(DC)STS-V8	Body	TV Antenna Module																																																												
D	2005	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																V																											
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2005	(DW)STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
D	2005	(DW)STS	Chassis	Electronic Brake Control Module																																																												
D	2005	(DW)STS	Chassis	Electronic Suspension Control																																																												
D	2005	(DW)STS	Body	Amplifier (Bose)																																																												
D	2005	(DW)STS	Body	Digital Radio Receiver																																																												
D	2005	(DW)STS	Body	Distance Sensing Cruise Control																																																												
D	2005	(DW)STS	Body	Driver Door Module																																																												
D	2005	(DW)STS	Body	Driver Door Switch																																																												
D	2005	(DW)STS	Body	Driver Position Module																																																												
D	2005	(DW)STS	Body	Headlamp Control Module																																																												
D	2005	(DW)STS	Body	Head Up Display																																																												
D	2005	(DW)STS	Body	HVAC Control Module																																												V															

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2005	(DW)STS	Body	Instrument Panel Cluster																																																										
D	2005	(DW)STS	Body	Instrument Panel Module																																																											
D	2005	(DW)STS	Body	Left Rear Door Module																																																											
D	2005	(DW)STS	Body	Passenger Door Module																																																											
D	2005	(DW)STS	Body	Uplevel Radio																																																											
D	2005	(DW)STS	Body	Navigation Radio																																																											
D	2005	(DW)STS	Body	Rear Integration Module																																																											
D	2005	(DW)STS	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DW)STS	Body	Right Rear Door Module																																																											
D	2005	(DW)STS	Body	Steering Column Lock Module																																																											
D	2005	(DW)STS	Body	Supplemental Inflatable Restraint																																																											
D	2005	(DW)STS	Body	TV Antenna Module																																																											
D	2005	(DW)STS	Body	Vehicle Comm. Interface Module																																V																											
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DM)CTS	Chassis	Tire Pressure Monitor																																																											
D	2006	(DM)CTS	Chassis	VES																																																											
D	2006	(DM)CTS	Body	Amplifier (Bose)																																																											
D	2006	(DM)CTS	Body	Amplifier (Delco)																																																											
D	2006	(DM)CTS	Body	Climate Control Panel																																												V															
D	2006	(DM)CTS	Body	Dash Integration Module																																																											
D	2006	(DM)CTS	Body	Digital Radio Receiver																																																											
D	2006	(DM)CTS	Body	Driver Door Switch																																																											
D	2006	(DM)CTS	Body	Driver Door Module																																																											
D	2006	(DM)CTS	Body	Passenger Door Module																																																											
D	2006	(DM)CTS	Body	Left Rear Door Module																																																											
D	2006	(DM)CTS	Body	Right Rear Door Module																																																											
D	2006	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DM)CTS	Body	Instrument Panel Cluster																																																											
D	2006	(DM)CTS	Body	Memory Seat Module																																																											
D	2006	(DM)CTS	Body	Personalization																																																											
D	2006	(DM)CTS	Body	Radio																																																											
D	2006	(DM)CTS	Body	Rear Integration Module																																																											
D	2006	(DM)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DM)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DM)CTS	Body	TV Antenna Module																																																											
D	2006	(DM)CTS	Body	Vehicle Theft Deterrent																																																											
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DP)CTS	Chassis	Tire Pressure Monitor																																																											
D	2006	(DP)CTS	Chassis	VES																																																											
D	2006	(DP)CTS	Body	Amplifier (Bose)																																																											
D	2006	(DP)CTS	Body	Amplifier (Delco)																																																											
D	2006	(DP)CTS	Body	Climate Control Panel																																												V															

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2006	(DP)CTS	Body	Dash Integration Module																																																									
D	2006	(DP)CTS	Body	Digital Radio Receiver																																																										
D	2006	(DP)CTS	Body	Driver Door Switch																																																										
D	2006	(DP)CTS	Body	Driver Door Module																																																										
D	2006	(DP)CTS	Body	Passenger Door Module																																																										
D	2006	(DP)CTS	Body	Left Rear Door Module																																																										
D	2006	(DP)CTS	Body	Right Rear Door Module																																																										
D	2006	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2006	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2006	(DP)CTS	Body	Instrument Panel Cluster																																																										
D	2006	(DP)CTS	Body	Memory Seat Module																																																										
D	2006	(DP)CTS	Body	Personalization																																																										
D	2006	(DP)CTS	Body	Radio																																																										
D	2006	(DP)CTS	Body	Rear Integration Module																																																										
D	2006	(DP)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2006	(DP)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2006	(DP)CTS	Body	TV Antenna Module																																																										
D	2006	(DP)CTS	Body	Vehicle Theft Deterrent																																																										
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2006	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2006	(DR)CTS	Chassis	Tire Pressure Monitor																																																										
D	2006	(DR)CTS	Chassis	VES																																																										
D	2006	(DR)CTS	Body	Amplifier (Bose)																																																										
D	2006	(DR)CTS	Body	Amplifier (Delco)																																																										
D	2006	(DR)CTS	Body	Climate Control Panel																																													V														
D	2006	(DR)CTS	Body	Dash Integration Module																																																										
D	2006	(DR)CTS	Body	Digital Radio Receiver																																																										
D	2006	(DR)CTS	Body	Driver Door Switch																																																										
D	2006	(DR)CTS	Body	Driver Door Module																																																										
D	2006	(DR)CTS	Body	Passenger Door Module																																																										
D	2006	(DR)CTS	Body	Left Rear Door Module																																																										
D	2006	(DR)CTS	Body	Right Rear Door Module																																																										
D	2006	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2006	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2006	(DR)CTS	Body	Instrument Panel Cluster																																																										
D	2006	(DR)CTS	Body	Memory Seat Module																																																										
D	2006	(DR)CTS	Body	Personalization																																																										
D	2006	(DR)CTS	Body	Radio																																																										
D	2006	(DR)CTS	Body	Rear Integration Module																																																										
D	2006	(DR)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2006	(DR)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2006	(DR)CTS	Body	TV Antenna Module																																																										
D	2006	(DR)CTS	Body	Vehicle Theft Deterrent																																																										
D	2006	(DN)CTS-V	Powertrain	Engine Control Module																																																										
D	2006	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																										
D	2006	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																										
D	2006	(DN)CTS-V	Chassis	VES																																																										
D	2006	(DN)CTS-V	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2006	(DN)CTS-V	Body	Amplifier (Delco)																																																									
D	2006	(DN)CTS-V	Body	Climate Control Panel																																												V												
D	2006	(DN)CTS-V	Body	Dash Integration Module																																																									
D	2006	(DN)CTS-V	Body	Digital Radio Receiver																																																									
D	2006	(DN)CTS-V	Body	Driver Door Switch																																																									
D	2006	(DN)CTS-V	Body	Driver Door Module																																																									
D	2006	(DN)CTS-V	Body	Passenger Door Module																																																									
D	2006	(DN)CTS-V	Body	Left Rear Door Module																																																									
D	2006	(DN)CTS-V	Body	Right Rear Door Module																																																									
D	2006	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																									
D	2006	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																									
D	2006	(DN)CTS-V	Body	Instrument Panel Cluster																																																									
D	2006	(DN)CTS-V	Body	Memory Seat Module																																																									
D	2006	(DN)CTS-V	Body	Personalization																																																									
D	2006	(DN)CTS-V	Body	Rear Integration Module																																																									
D	2006	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																									
D	2006	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																									
D	2006	(DN)CTS-V	Body	TV Antenna Module																																																									
D	2006	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																									
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Engine Controls																																																									
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																									
D	2006	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																									
D	2006	(DC)STS-V8	Chassis	Electronic Suspension Control																																																									
D	2006	(DC)STS-V8	Body	Amplifier (Bose)																																																									
D	2006	(DC)STS-V8	Body	Digital Radio Receiver																																																									
D	2006	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																									
D	2006	(DC)STS-V8	Body	Driver Door Module																																																									
D	2006	(DC)STS-V8	Body	Driver Door Switch																																																									
D	2006	(DC)STS-V8	Body	Driver Position Module																																																									
D	2006	(DC)STS-V8	Body	Headlamp Control Module																																																									
D	2006	(DC)STS-V8	Body	Head Up Display																																																									
D	2006	(DC)STS-V8	Body	HVAC Control Module																																												V												
D	2006	(DC)STS-V8	Body	Instrument Panel Cluster																																																									
D	2006	(DC)STS-V8	Body	Instrument Panel Module																																																									
D	2006	(DC)STS-V8	Body	Left Rear Door Module																																																									
D	2006	(DC)STS-V8	Body	Passenger Door Module																																																									
D	2006	(DC)STS-V8	Body	Uplevel Radio																																																									
D	2006	(DC)STS-V8	Body	Navigation Radio																																																									
D	2006	(DC)STS-V8	Body	Rear Integration Module																																																									
D	2006	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																									
D	2006	(DC)STS-V8	Body	Right Rear Door Module																																																									
D	2006	(DC)STS-V8	Body	Steering Column Lock Module																																																									
D	2006	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																									
D	2006	(DC)STS-V8	Body	TV Antenna Module																																																									
D	2006	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																V																									
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																									
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
D	2006	(DW)STS	Chassis	Electronic Brake Control Module																																																									
D	2006	(DW)STS	Chassis	Electronic Suspension Control																																																									
D	2006	(DW)STS	Body	Amplifier (Bose)																																																									
D	2006	(DW)STS	Body	Digital Radio Receiver																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2006	(DW)STS	Body	Distance Sensing Cruise Control																																																								
D	2006	(DW)STS	Body	Driver Door Module																																																								
D	2006	(DW)STS	Body	Driver Door Switch																																																								
D	2006	(DW)STS	Body	Driver Position Module																																																								
D	2006	(DW)STS	Body	Headlamp Control Module																																																								
D	2006	(DW)STS	Body	Head Up Display																																																								
D	2006	(DW)STS	Body	HVAC Control Module																																																								
D	2006	(DW)STS	Body	Instrument Panel Cluster																																																								
D	2006	(DW)STS	Body	Instrument Panel Module																																																								
D	2006	(DW)STS	Body	Left Rear Door Module																																																								
D	2006	(DW)STS	Body	Passenger Door Module																																																								
D	2006	(DW)STS	Body	Uplevel Radio																																																								
D	2006	(DW)STS	Body	Navigation Radio																																																								
D	2006	(DW)STS	Body	Rear Integration Module																																																								
D	2006	(DW)STS	Body	Remote Control Door Lock Receiver																																																								
D	2006	(DW)STS	Body	Right Rear Door Module																																																								
D	2006	(DW)STS	Body	Steering Column Lock Module																																																								
D	2006	(DW)STS	Body	Supplemental Inflatable Restraint																																																								
D	2006	(DW)STS	Body	TV Antenna Module																																																								
D	2006	(DW)STS	Body	Vehicle Comm. Interface Module																																	V																							
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																								
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																								
D	2006	(DX)STS-V	Chassis	Electronic Brake Control Module																																																								
D	2006	(DX)STS-V	Chassis	Electronic Suspension Control																																																								
D	2006	(DX)STS-V	Body	Amplifier (Bose)																																																								
D	2006	(DX)STS-V	Body	Digital Radio Receiver																																																								
D	2006	(DX)STS-V	Body	Distance Sensing Cruise Control																																																								
D	2006	(DX)STS-V	Body	Driver Door Module																																																								
D	2006	(DX)STS-V	Body	Driver Door Switch																																																								
D	2006	(DX)STS-V	Body	Driver Position Module																																																								
D	2006	(DX)STS-V	Body	Headlamp Control Module																																																								
D	2006	(DX)STS-V	Body	Head Up Display																																																								
D	2006	(DX)STS-V	Body	HVAC Control Module																																																								
D	2006	(DX)STS-V	Body	Instrument Panel Cluster																																																								
D	2006	(DX)STS-V	Body	Instrument Panel Module																																																								
D	2006	(DX)STS-V	Body	Left Rear Door Module																																																								
D	2006	(DX)STS-V	Body	Passenger Door Module																																																								
D	2006	(DX)STS-V	Body	Uplevel Radio																																																								
D	2006	(DX)STS-V	Body	Navigation Radio																																																								
D	2006	(DX)STS-V	Body	Rear Integration Module																																																								
D	2006	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																								
D	2006	(DX)STS-V	Body	Right Rear Door Module																																																								
D	2006	(DX)STS-V	Body	Steering Column Lock Module																																																								
D	2006	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																								
D	2006	(DX)STS-V	Body	TV Antenna Module																																																								
D	2006	(DX)STS-V	Body	Vehicle Comm. Interface Module																																	V																							
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																								
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																								
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																								
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																								
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2007	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																									
D	2007	(DM)CTS	Chassis	VES																																																									
D	2007	(DM)CTS	Body	Amplifier (Bose)																																																									
D	2007	(DM)CTS	Body	Amplifier (Delco)																																																									
D	2007	(DM)CTS	Body	Climate Control Panel																																												V													
D	2007	(DM)CTS	Body	Dash Integration Module																																																									
D	2007	(DM)CTS	Body	Digital Radio Receiver																																																									
D	2007	(DM)CTS	Body	Driver Door Switch																																																									
D	2007	(DM)CTS	Body	Driver Door Module																																																									
D	2007	(DM)CTS	Body	Passenger Door Module																																																									
D	2007	(DM)CTS	Body	Left Rear Door Module																																																									
D	2007	(DM)CTS	Body	Right Rear Door Module																																																									
D	2007	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																									
D	2007	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																									
D	2007	(DM)CTS	Body	Instrument Panel Cluster																																																									
D	2007	(DM)CTS	Body	Memory Seat Module																																																									
D	2007	(DM)CTS	Body	Personalization																																																									
D	2007	(DM)CTS	Body	Rear Integration Module																																																									
D	2007	(DM)CTS	Body	Remote Control Door Lock Receiver																																																									
D	2007	(DM)CTS	Body	Supplemental Inflatable Restraint																																																									
D	2007	(DM)CTS	Body	Theft Deterrent Module																																																									
D	2007	(DM)CTS	Body	TV Antenna Module																																																									
D	2007	(DM)CTS	Body	Vehicle Comm. Interface Module																																V																									
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																									
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																									
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																									
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																									
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																									
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
D	2007	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																									
D	2007	(DP)CTS	Chassis	VES																																																									
D	2007	(DP)CTS	Body	Amplifier (Bose)																																																									
D	2007	(DP)CTS	Body	Amplifier (Delco)																																																									
D	2007	(DP)CTS	Body	Climate Control Panel																																												V													
D	2007	(DP)CTS	Body	Dash Integration Module																																																									
D	2007	(DP)CTS	Body	Digital Radio Receiver																																																									
D	2007	(DP)CTS	Body	Driver Door Switch																																																									
D	2007	(DP)CTS	Body	Driver Door Module																																																									
D	2007	(DP)CTS	Body	Passenger Door Module																																																									
D	2007	(DP)CTS	Body	Left Rear Door Module																																																									
D	2007	(DP)CTS	Body	Right Rear Door Module																																																									
D	2007	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																									
D	2007	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																									
D	2007	(DP)CTS	Body	Instrument Panel Cluster																																																									
D	2007	(DP)CTS	Body	Memory Seat Module																																																									
D	2007	(DP)CTS	Body	Personalization																																																									
D	2007	(DP)CTS	Body	Rear Integration Module																																																									
D	2007	(DP)CTS	Body	Remote Control Door Lock Receiver																																																									
D	2007	(DP)CTS	Body	Supplemental Inflatable Restraint																																																									
D	2007	(DP)CTS	Body	Theft Deterrent Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2007	(DP)CTS	Body	TV Antenna Module																																																								
D	2007	(DP)CTS	Body	Vehicle Comm. Interface Module																																		V																						
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																								
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																								
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																								
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																								
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																								
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2007	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																								
D	2007	(DR)CTS	Chassis	VES																																																								
D	2007	(DR)CTS	Body	Amplifier (Bose)																																																								
D	2007	(DR)CTS	Body	Amplifier (Delco)																																																								
D	2007	(DR)CTS	Body	Climate Control Panel																																											V													
D	2007	(DR)CTS	Body	Dash Integration Module																																																								
D	2007	(DR)CTS	Body	Digital Radio Receiver																																																								
D	2007	(DR)CTS	Body	Driver Door Switch																																																								
D	2007	(DR)CTS	Body	Driver Door Module																																																								
D	2007	(DR)CTS	Body	Passenger Door Module																																																								
D	2007	(DR)CTS	Body	Left Rear Door Module																																																								
D	2007	(DR)CTS	Body	Right Rear Door Module																																																								
D	2007	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																								
D	2007	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																								
D	2007	(DR)CTS	Body	Instrument Panel Cluster																																																								
D	2007	(DR)CTS	Body	Memory Seat Module																																																								
D	2007	(DR)CTS	Body	Personalization																																																								
D	2007	(DR)CTS	Body	Rear Integration Module																																																								
D	2007	(DR)CTS	Body	Remote Control Door Lock Receiver																																																								
D	2007	(DR)CTS	Body	Supplemental Inflatable Restraint																																																								
D	2007	(DR)CTS	Body	Theft Deterrent Module																																																								
D	2007	(DR)CTS	Body	TV Antenna Module																																																								
D	2007	(DR)CTS	Body	Vehicle Comm. Interface Module																																		V																						
D	2007	(DN)CTS-V	Powertrain	(U)6.0L V8 LS2 Engine Control Module																																																								
D	2007	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																								
D	2007	(DN)CTS-V	Chassis	VES																																																								
D	2007	(DN)CTS-V	Body	Amplifier (Bose)																																																								
D	2007	(DN)CTS-V	Body	Amplifier (Delco)																																																								
D	2007	(DN)CTS-V	Body	Climate Control Panel																																											V													
D	2007	(DN)CTS-V	Body	Dash Integration Module																																																								
D	2007	(DN)CTS-V	Body	Digital Radio Receiver																																																								
D	2007	(DN)CTS-V	Body	Driver Door Switch																																																								
D	2007	(DN)CTS-V	Body	Driver Door Module																																																								
D	2007	(DN)CTS-V	Body	Passenger Door Module																																																								
D	2007	(DN)CTS-V	Body	Left Rear Door Module																																																								
D	2007	(DN)CTS-V	Body	Right Rear Door Module																																																								
D	2007	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																								
D	2007	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																								
D	2007	(DN)CTS-V	Body	Instrument Panel Cluster																																																								
D	2007	(DN)CTS-V	Body	Memory Seat Module																																																								
D	2007	(DN)CTS-V	Body	Personalization																																																								
D	2007	(DN)CTS-V	Body	Rear Integration Module																																																								
D	2007	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2007	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																								
D	2007	(DN)CTS-V	Body	Theft Deterrent Module																																																								
D	2007	(DN)CTS-V	Body	TV Antenna Module																																																								
D	2007	(DN)CTS-V	Body	Vehicle Comm. Interface Module																																	V																							
D	2007	(DC)STS-V8	Powertrain	Engine Control Module																																																								
D	2007	(DC)STS-V8	Powertrain	Transmission Control Module																																																								
D	2007	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																								
D	2007	(DC)STS-V8	Chassis	Electronic Suspension Control																																																								
D	2007	(DC)STS-V8	Body	Amplifier (Bose)																																																								
D	2007	(DC)STS-V8	Body	Digital Radio Receiver																																																								
D	2007	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																								
D	2007	(DC)STS-V8	Body	Driver Door Module																																																								
D	2007	(DC)STS-V8	Body	Driver Door Switch																																																								
D	2007	(DC)STS-V8	Body	Driver Position Module																																																								
D	2007	(DC)STS-V8	Body	Headlamp Control Module																																																								
D	2007	(DC)STS-V8	Body	Head Up Display																																																								
D	2007	(DC)STS-V8	Body	HVAC Control Module																																											V													
D	2007	(DC)STS-V8	Body	Instrument Panel Cluster																																																								
D	2007	(DC)STS-V8	Body	Instrument Panel Module																																																								
D	2007	(DC)STS-V8	Body	Left Rear Door Module																																																								
D	2007	(DC)STS-V8	Body	Passenger Door Module																																																								
D	2007	(DC)STS-V8	Body	Uplevel Radio																																																								
D	2007	(DC)STS-V8	Body	Navigation Radio																																																								
D	2007	(DC)STS-V8	Body	Rear Integration Module																																																								
D	2007	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																								
D	2007	(DC)STS-V8	Body	Right Rear Door Module																																																								
D	2007	(DC)STS-V8	Body	Steering Column Lock Module																																																								
D	2007	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																								
D	2007	(DC)STS-V8	Body	TV Antenna Module																																																								
D	2007	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																	V																							
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2007	(DW)STS	Chassis	Electronic Brake Control Module																																																								
D	2007	(DW)STS	Chassis	Electronic Suspension Control																																																								
D	2007	(DW)STS	Body	Amplifier (Bose)																																																								
D	2007	(DW)STS	Body	Digital Radio Receiver																																																								
D	2007	(DW)STS	Body	Distance Sensing Cruise Control																																																								
D	2007	(DW)STS	Body	Driver Door Module																																																								
D	2007	(DW)STS	Body	Driver Door Switch																																																								
D	2007	(DW)STS	Body	Driver Position Module																																																								
D	2007	(DW)STS	Body	Headlamp Control Module																																																								
D	2007	(DW)STS	Body	Head Up Display																																																								
D	2007	(DW)STS	Body	HVAC Control Module																																											V													
D	2007	(DW)STS	Body	Instrument Panel Cluster																																																								
D	2007	(DW)STS	Body	Instrument Panel Module																																																								
D	2007	(DW)STS	Body	Left Rear Door Module																																																								
D	2007	(DW)STS	Body	Passenger Door Module																																																								
D	2007	(DW)STS	Body	Uplevel Radio																																																								
D	2007	(DW)STS	Body	Navigation Radio																																																								
D	2007	(DW)STS	Body	Rear Integration Module																																																								
D	2007	(DW)STS	Body	Remote Control Door Lock Receiver																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2007	(DW)STS	Body	Right Rear Door Module																																																									
D	2007	(DW)STS	Body	Steering Column Lock Module																																																										
D	2007	(DW)STS	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DW)STS	Body	TV Antenna Module																																																										
D	2007	(DW)STS	Body	Vehicle Comm. Interface Module																																V																											
D	2007	(DX)STS-V	Powertrain	Engine Control Module																																																										
D	2007	(DX)STS-V	Powertrain	Transmission Control Module																																																										
D	2007	(DX)STS-V	Chassis	Electronic Brake Control Module																																																										
D	2007	(DX)STS-V	Chassis	Electronic Suspension Control																																																										
D	2007	(DX)STS-V	Body	Amplifier (Bose)																																																										
D	2007	(DX)STS-V	Body	Digital Radio Receiver																																																										
D	2007	(DX)STS-V	Body	Distance Sensing Cruise Control																																																										
D	2007	(DX)STS-V	Body	Driver Door Module																																																										
D	2007	(DX)STS-V	Body	Driver Door Switch																																																										
D	2007	(DX)STS-V	Body	Driver Position Module																																																										
D	2007	(DX)STS-V	Body	Headlamp Control Module																																																										
D	2007	(DX)STS-V	Body	Head Up Display																																																										
D	2007	(DX)STS-V	Body	HVAC Control Module																																													V														
D	2007	(DX)STS-V	Body	Instrument Panel Cluster																																																										
D	2007	(DX)STS-V	Body	Instrument Panel Module																																																										
D	2007	(DX)STS-V	Body	Left Rear Door Module																																																										
D	2007	(DX)STS-V	Body	Passenger Door Module																																																										
D	2007	(DX)STS-V	Body	Uplevel Radio																																																										
D	2007	(DX)STS-V	Body	Navigation Radio																																																										
D	2007	(DX)STS-V	Body	Rear Integration Module																																																										
D	2007	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																										
D	2007	(DX)STS-V	Body	Right Rear Door Module																																																										
D	2007	(DX)STS-V	Body	Steering Column Lock Module																																																										
D	2007	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DX)STS-V	Body	TV Antenna Module																																																										
D	2007	(DX)STS-V	Body	Vehicle Comm. Interface Module																																V																											
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																										
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																										
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																										
D	2008	CTS	Chassis	Electronic Brake Control Module																																																										
D	2008	CTS	Body	Body Control Module																																																										
D	2008	CTS	Body	Body Control Module (aux.)																																																										
D	2008	CTS	Body	Driver Door Switch																																																										
D	2008	CTS	Body	Headlamp Control Module																																																										
D	2008	CTS	Body	HVAC Control Module																																													V														
D	2008	CTS	Body	Infotainment Faceplate Module																																																										
D	2008	CTS	Body	Instrument Panel Cluster																																																										
D	2008	CTS	Body	Memory Seat Module																																																										
D	2008	CTS	Body	Park Assist Module																																																										
D	2008	CTS	Body	Passenger Door Switch																																																										
D	2008	CTS	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2008	CTS	Body	Pedestrian Impact Detection Module																																																												
D	2008	CTS	Body	Radio																																																												
D	2008	CTS	Body	Supplemental Inflatable Restraint																																																												
D	2008	CTS	Body	TV Antenna Module																																																												
D	2008	CTS	Body	Vehicle Comm. Interface Module																																V																												
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																												
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
D	2008	SLS	Chassis	Electronic Brake Control Module																																																												
D	2008	SLS	Chassis	Electronic Suspension Control																																																												
D	2008	SLS	Body	Amplifier (Bose)																																																												
D	2008	SLS	Body	Driver Door Module																																																												
D	2008	SLS	Body	Driver Door Switch																																																												
D	2008	SLS	Body	Driver Position Module																																																												
D	2008	SLS	Body	Headlamp Control Module																																																												
D	2008	SLS	Body	HVAC Control Module																																												V																
D	2008	SLS	Body	Instrument Panel Cluster																																																												
D	2008	SLS	Body	Instrument Panel Module																																																												
D	2008	SLS	Body	Left Rear Door Module																																																												
D	2008	SLS	Body	Passenger Door Module																																																												
D	2008	SLS	Body	Radio																																																												
D	2008	SLS	Body	Rear HVAC/RSA																																																												
D	2008	SLS	Body	Rear Integration Module																																																												
D	2008	SLS	Body	Remote Control Door Lock Receiver																																																												
D	2008	SLS	Body	Right Rear Door Module																																																												
D	2008	SLS	Body	Supplemental Inflatable Restraint																																																												
D	2008	SLS	Body	TV Antenna Module																																																												
D	2008	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																												
D	2008	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																												
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																												
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																												
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
D	2008	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																												
D	2008	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																												
D	2008	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																												
D	2008	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																												
D	2008	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																												
D	2008	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																												
D	2008	STS	Body	Amplifier (Bose)																																																												
D	2008	STS	Body	Digital Radio Receiver																																																												
D	2008	STS	Body	Distance Sensing Cruise Control																																																												
D	2008	STS	Body	Driver Door Module																																																												
D	2008	STS	Body	Driver Door Switch																																																												
D	2008	STS	Body	Driver Position Module																																																												
D	2008	STS	Body	Headlamp Control Module																																																												
D	2008	STS	Body	Head Up Display																																																												
D	2008	STS	Body	HVAC Control Module																																												V																

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2008	STS	Body	Instrument Panel Cluster																																																									
D	2008	STS	Body	Instrument Panel Module																																																										
D	2008	STS	Body	Left Rear Door Module																																																										
D	2008	STS	Body	Left Side Object Detection Module																																																										
D	2008	STS	Body	Passenger Door Module																																																										
D	2008	STS	Body	Uplevel Radio																																																										
D	2008	STS	Body	Navigation Radio																																																										
D	2008	STS	Body	Rear Integration Module																																																										
D	2008	STS	Body	Remote Control Door Lock Receiver																																																											
D	2008	STS	Body	Right Rear Door Module																																																											
D	2008	STS	Body	Right Side Object Detection Module																																																											
D	2008	STS	Body	Steering Column Lock Module																																																											
D	2008	STS	Body	Supplemental Inflatable Restraint																																																											
D	2008	STS	Body	TV Antenna Module																																																											
D	2008	STS	Body	Vehicle Comm. Interface Module																																	V																											
D	2008	STS	Body	Veh Direction Alert Alarm Warn Mod																																																											
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																											
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																											
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																											
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																											
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																											
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																											
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																											
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																											
D	2009	CTS	Chassis	Electronic Brake Control Module																																																											
D	2009	CTS	Chassis	Electronic Suspension Control																																																											
D	2009	CTS	Chassis	Parking Brake Control Module																																																											
D	2009	CTS	Body	Body Control Module																																																										
D	2009	CTS	Body	Body Control Module (aux.)																																																											
D	2009	CTS	Body	Driver Door Switch																																																											
D	2009	CTS	Body	Headlamp Control Module																																																											
D	2009	CTS	Body	HVAC Control Module																																													V															
D	2009	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																											
D	2009	CTS	Body	Instrument Panel Cluster (Other)																																																											
D	2009	CTS	Body	Memory Seat Module																																																											
D	2009	CTS	Body	Park Assist Module																																																											
D	2009	CTS	Body	Passenger Door Switch																																																											
D	2009	CTS	Body	Passenger Presence System																																																											
D	2009	CTS	Body	Pedestrian Impact Detection Module																																																											
D	2009	CTS	Body	Radio																																																											
D	2009	CTS	Body	Supplemental Inflatable Restraint																																																											
D	2009	CTS	Body	TV Antenna Module																																																											
D	2009	CTS	Body	Vehicle Comm. Interface Module																																	V																											
D	2009	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2009	SLS	Powertrain	(T)2.8L V6 LP2 Transmission Control Module																																																											
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
D	2009	SLS	Chassis	Electronic Brake Control Module																																																												
D	2009	SLS	Chassis	Electronic Suspension Control																																																												
D	2009	SLS	Body	Amplifier (Bose)																																																												
D	2009	SLS	Body	Driver Door Module																																																												
D	2009	SLS	Body	Driver Door Switch																																																												
D	2009	SLS	Body	Driver Position Module																																																												
D	2009	SLS	Body	Headlamp Control Module																																																												
D	2009	SLS	Body	HVAC Control Module																																												V																
D	2009	SLS	Body	Instrument Panel Cluster																																																												
D	2009	SLS	Body	Instrument Panel Module																																																												
D	2009	SLS	Body	Left Rear Door Module																																																												
D	2009	SLS	Body	Passenger Door Module																																																												
D	2009	SLS	Body	Radio																																																												
D	2009	SLS	Body	Rear HVAC/RSA																																																												
D	2009	SLS	Body	Rear Integration Module																																																												
D	2009	SLS	Body	Remote Control Door Lock Receiver																																																												
D	2009	SLS	Body	Right Rear Door Module																																																												
D	2009	SLS	Body	Supplemental Inflatable Restraint																																																												
D	2009	SLS	Body	TV Antenna Module																																																												
D	2009	SLS	Body	Vehicle Comm. Interface Module																																V		V																									
D	2009	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																												
D	2009	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																												
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																												
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																												
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
D	2009	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																												
D	2009	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																												
D	2009	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																												
D	2009	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																												
D	2009	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																												
D	2009	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																												
D	2009	STS	Body	Amplifier (Bose)																																																												
D	2009	STS	Body	Digital Radio Receiver																																																												
D	2009	STS	Body	Distance Sensing Cruise Control																																																												
D	2009	STS	Body	Driver Door Module																																																												
D	2009	STS	Body	Driver Door Switch																																																												
D	2009	STS	Body	Driver Position Module																																																												
D	2009	STS	Body	Headlamp Control Module																																																												
D	2009	STS	Body	Head Up Display																																																												
D	2009	STS	Body	HVAC Control Module																																												V																
D	2009	STS	Body	Instrument Panel Cluster																																																												
D	2009	STS	Body	Instrument Panel Module																																																												
D	2009	STS	Body	Left Rear Door Module																																																												
D	2009	STS	Body	Left Side Object Detection Module																																																												
D	2009	STS	Body	Passenger Door Module																																																												
D	2009	STS	Body	Uplevel Radio																																																												
D	2009	STS	Body	Navigation Radio																																																												
D	2009	STS	Body	Rear Integration Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2009	STS	Body	Remote Control Door Lock Receiver																																																									
D	2009	STS	Body	Right Rear Door Module																																																										
D	2009	STS	Body	Right Side Object Detection Module																																																										
D	2009	STS	Body	Steering Column Lock Module																																																										
D	2009	STS	Body	Supplemental Inflatable Restraint																																																										
D	2009	STS	Body	TV Antenna Module																																																										
D	2009	STS	Body	Vehicle Comm. Interface Module																																	V																										
D	2009	STS	Body	Veh Direction Alert Alarm Warn Mod																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Auto																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Manual																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transmission Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transfer Case Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module Auto																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																										
D	2010	CTS	Chassis	Electronic Brake Control Module																																																										
D	2010	CTS	Chassis	Electronic Suspension Control																																																										
D	2010	CTS	Chassis	Parking Brake Control Module																																																										
D	2010	CTS	Body	Body Control Module																																																										
D	2010	CTS	Body	Body Control Module (aux.)																																																										
D	2010	CTS	Body	Driver Door Switch																																																										
D	2010	CTS	Body	Headlamp Control Module																																																										
D	2010	CTS	Body	HVAC Control Module																																												V														
D	2010	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																										
D	2010	CTS	Body	Instrument Panel Cluster (Other)																																																										
D	2010	CTS	Body	Liftgate Module																																																										
D	2010	CTS	Body	Memory Seat Module																																																										
D	2010	CTS	Body	Park Assist Module																																																										
D	2010	CTS	Body	Passenger Door Switch																																																										
D	2010	CTS	Body	Passenger Presence System																																																										
D	2010	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2010	CTS	Body	Radio																																																										
D	2010	CTS	Body	Supplemental Inflatable Restraint																									V	V																																
D	2010	CTS	Body	TV Antenna Module																																																										
D	2010	CTS	Body	Vehicle Comm. Interface Module																																	V		V																							
D	2010	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																										
D	2010	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2010	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																										
D	2010	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2010	STS	Body	Amplifier (Bose)																																																									
D	2010	STS	Body	Digital Radio Receiver																																																										
D	2010	STS	Body	Distance Sensing Cruise Control																																																										
D	2010	STS	Body	Driver Door Module																																																										
D	2010	STS	Body	Driver Door Switch																																																										
D	2010	STS	Body	Driver Position Module																																																										
D	2010	STS	Body	Headlamp Control Module																																																										
D	2010	STS	Body	Head Up Display																																																										
D	2010	STS	Body	HVAC Control Module																																												V														
D	2010	STS	Body	Instrument Panel Cluster																																																										
D	2010	STS	Body	Instrument Panel Module																																																										
D	2010	STS	Body	Left Rear Door Module																																																										
D	2010	STS	Body	Left Side Object Detection Module																																																										
D	2010	STS	Body	Passenger Door Module																																																										
D	2010	STS	Body	Uplevel Radio																																																										
D	2010	STS	Body	Navigation Radio																																																										
D	2010	STS	Body	Rear Integration Module																																																										
D	2010	STS	Body	Remote Control Door Lock Receiver																																																											
D	2010	STS	Body	Right Rear Door Module																																																										
D	2010	STS	Body	Right Side Object Detection Module																																																										
D	2010	STS	Body	Steering Column Lock Module																																																										
D	2010	STS	Body	Supplemental Inflatable Restraint																																																										
D	2010	STS	Body	TV Antenna Module																																																										
D	2010	STS	Body	Vehicle Comm. Interface Module																																	V		V																							
D	2010	STS	Body	Veh Direction Alert Alarm Warn Mod																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Auto																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Manual																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transfer Case Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Fuel Pump Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transfer Case Control Module																																																										
D	2011	CTS	Chassis	Electronic Brake Control Module																																																										
D	2011	CTS	Chassis	Electronic Suspension Control																																																										
D	2011	CTS	Chassis	Parking Brake Control Module																																																										
D	2011	CTS	Body	Body Control Module (6.2L V8 LSA)																																																										
D	2011	CTS	Body	Body Control Module (Other)																																																										
D	2011	CTS	Body	Body Control Module (aux.)																																																										
D	2011	CTS	Body	Driver Door Switch																																																										
D	2011	CTS	Body	Headlamp Control Module																																																										
D	2011	CTS	Body	HVAC Control Module																																												V														
D	2011	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																										
D	2011	CTS	Body	Instrument Panel Cluster (Other)																																																										
D	2011	CTS	Body	Liftgate Module																																																										
D	2011	CTS	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2011	CTS	Body	Park Assist Module																																																								
D	2011	CTS	Body	Passenger Door Switch																																																								
D	2011	CTS	Body	Passenger Presence System																																																								
D	2011	CTS	Body	Pedestrian Impact Detection Module																																																								
D	2011	CTS	Body	Radio																																																								
D	2011	CTS	Body	Supplemental Inflatable Restraint																									V	V																														
D	2011	CTS	Body	TV Antenna Module																																																								
D	2011	CTS	Body	Vehicle Comm. Interface Module																																	V		V																					
D	2011	STS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																								
D	2011	STS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																								
D	2011	STS	Chassis	Electronic Brake Control Module																																																								
D	2011	STS	Chassis	Electronic Suspension Control																																																								
D	2011	STS	Body	Amplifier (Bose)																																																								
D	2011	STS	Body	Digital Radio Receiver																																																								
D	2011	STS	Body	Distance Sensing Cruise Control																																																								
D	2011	STS	Body	Driver Door Module																																																								
D	2011	STS	Body	Driver Door Switch																																																								
D	2011	STS	Body	Driver Position Module																																																								
D	2011	STS	Body	Headlamp Control Module																																																								
D	2011	STS	Body	Head Up Display																																																								
D	2011	STS	Body	HVAC Control Module																																											V													
D	2011	STS	Body	Instrument Panel Cluster																																																								
D	2011	STS	Body	Instrument Panel Module																																																								
D	2011	STS	Body	Left Rear Door Module																																																								
D	2011	STS	Body	Left Side Object Detection Module																																																								
D	2011	STS	Body	Passenger Door Module																																																								
D	2011	STS	Body	Uplevel Radio																																																								
D	2011	STS	Body	Navigation Radio																																																								
D	2011	STS	Body	Rear Integration Module																																																								
D	2011	STS	Body	Remote Control Door Lock Receiver																																																								
D	2011	STS	Body	Right Rear Door Module																																																								
D	2011	STS	Body	Right Side Object Detection Module																																																								
D	2011	STS	Body	Supplemental Inflatable Restraint																																																								
D	2011	STS	Body	TV Antenna Module																																																								
D	2011	STS	Body	Vehicle Comm. Interface Module																																	V		V																					
D	2011	STS	Body	Veh Direction Alert Alarm Warn Mod																																																								
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																								
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																								
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																								
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																								
D	2012	P Type Engine	Chassis	Electronic Brake Control Module																																																								
D	2012	P Type Engine	Chassis	Electronic Suspension Control																																																								
D	2012	P Type Engine	Chassis	Parking Brake Control Module																																																								
D	2012	P Type Engine	Body	Body Control Module																																																								
D	2012	P Type Engine	Body	Body Control Module (aux.)																																																								
D	2012	P Type Engine	Body	Driver Door Switch																																																								
D	2012	P Type Engine	Body	Headlamp Control Module																																																								
D	2012	P Type Engine	Body	HVAC Control Module																																											V													
D	2012	P Type Engine	Body	Instrument Panel Cluster																																																								
D	2012	P Type Engine	Body	Left Side Object Detection Module																																																								
D	2012	P Type Engine	Body	Liftgate Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2012	P Type Engine	Body	Memory Seat Module																																																									
D	2012	P Type Engine	Body	Park Assist Module																																																										
D	2012	P Type Engine	Body	Passenger Door Switch																																																										
D	2012	P Type Engine	Body	Passenger Presence System																																																										
D	2012	P Type Engine	Body	Pedestrian Impact Detection Module																																																										
D	2012	P Type Engine	Body	Radio																																																										
D	2012	P Type Engine	Body	Right Side Object Detection Module																																																										
D	2012	P Type Engine	Body	Supplemental Inflatable Restraint																									V	V																																
D	2012	P Type Engine	Body	TV Antenna Module																																																										
D	2012	P Type Engine	Body	Vehicle Comm. Interface Module																																	V		V																								
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto																				V																																						
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual																																																											
D	2012	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																											
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																											
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																											
D	2012	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module																				V																																							
D	2012	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																											
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																											
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																											
D	2012	Other	Chassis	Electronic Brake Control Module																																																											
D	2012	Other	Chassis	Electronic Suspension Control																																																											
D	2012	Other	Chassis	Parking Brake Control Module																																																											
D	2012	Other	Body	Body Control Module																																																										
D	2012	Other	Body	Body Control Module (aux.)																																																										
D	2012	Other	Body	Driver Door Switch																																																										
D	2012	Other	Body	Headlamp Control Module																																																										
D	2012	Other	Body	HVAC Control Module																																												V														
D	2012	Other	Body	Instrument Panel Cluster																																																										
D	2012	Other	Body	Left Side Object Detection Module																																																										
D	2012	Other	Body	Liftgate Module																																																										
D	2012	Other	Body	Memory Seat Module																																																										
D	2012	Other	Body	Park Assist Module																																																										
D	2012	Other	Body	Passenger Door Switch																																																										
D	2012	Other	Body	Passenger Presence System																																																										
D	2012	Other	Body	Pedestrian Impact Detection Module																																																										
D	2012	Other	Body	Radio																																																										
D	2012	Other	Body	Right Side Object Detection Module																																																										
D	2012	Other	Body	Supplemental Inflatable Restraint																									V	V																																
D	2012	Other	Body	TV Antenna Module																																																										
D	2012	Other	Body	Vehicle Comm. Interface Module																																	V		V																								
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2013	P Type Engine	Chassis	Electronic Brake Control Module																																																										
D	2013	P Type Engine	Chassis	Electronic Suspension Control																																																										
D	2013	P Type Engine	Chassis	Parking Brake Control Module																																																										
D	2013	P Type Engine	Body	Body Control Module																																																										
D	2013	P Type Engine	Body	Body Control Module (aux.)																																																										
D	2013	P Type Engine	Body	Driver Door Switch																																																										
D	2013	P Type Engine	Body	Headlamp Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2013	P Type Engine	Body	HVAC Control Module																																												V											
D	2013	P Type Engine	Body	Instrument Panel Cluster																																																						
D	2013	P Type Engine	Body	Left Side Object Detection Module																																																						
D	2013	P Type Engine	Body	Liftgate Module																																																						
D	2013	P Type Engine	Body	Memory Seat Module																																																						
D	2013	P Type Engine	Body	Park Assist Module																																																						
D	2013	P Type Engine	Body	Passenger Door Switch																																																						
D	2013	P Type Engine	Body	Passenger Presence System																																																						
D	2013	P Type Engine	Body	Pedestrian Impact Detection Module																																																						
D	2013	P Type Engine	Body	Radio																																																						
D	2013	P Type Engine	Body	Right Side Object Detection Module																																																						
D	2013	P Type Engine	Body	Supplemental Inflatable Restraint																									V	V																													
D	2013	P Type Engine	Body	TV Antenna Module																																																						
D	2013	P Type Engine	Body	Vehicle Comm. Interface Module																																	V		V																				
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto																				V																																			
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual																																																						
D	2013	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																						
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																						
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																						
D	2013	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module																				V																																			
D	2013	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																						
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																						
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																						
D	2013	Other	Chassis	Electronic Brake Control Module																																																						
D	2013	Other	Chassis	Electronic Suspension Control																																																						
D	2013	Other	Chassis	Parking Brake Control Module																																																						
D	2013	Other	Body	Body Control Module																																																						
D	2013	Other	Body	Body Control Module (aux.)																																																						
D	2013	Other	Body	Driver Door Switch																																																						
D	2013	Other	Body	Headlamp Control Module																																																						
D	2013	Other	Body	HVAC Control Module																																												V											
D	2013	Other	Body	Instrument Panel Cluster																																																						
D	2013	Other	Body	Left Side Object Detection Module																																																						
D	2013	Other	Body	Liftgate Module																																																						
D	2013	Other	Body	Memory Seat Module																																																						
D	2013	Other	Body	Park Assist Module																																																						
D	2013	Other	Body	Passenger Door Switch																																																						
D	2013	Other	Body	Passenger Presence System																																																						
D	2013	Other	Body	Pedestrian Impact Detection Module																																																						
D	2013	Other	Body	Radio																																																						
D	2013	Other	Body	Right Side Object Detection Module																																																						
D	2013	Other	Body	Supplemental Inflatable Restraint																									V	V																													
D	2013	Other	Body	TV Antenna Module																																																						
D	2013	Other	Body	Vehicle Comm. Interface Module																																	V		V																				
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																			
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																						
D	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																						
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																						
D	2014	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																						
D	2014	CTS	Powertrain	Chassis Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2014	CTS	Powertrain	Transfer Case Control Module																																																								
D	2014	CTS	Chassis	Electronic Brake Control Module					V																																																			
D	2014	CTS	Chassis	Parking Brake Control Module																																																								
D	2014	CTS	Chassis	Suspension Control Module																																																								
D	2014	CTS	Body	Body Control Module Coupe						V	V	V						V					V	V																																				
D	2014	CTS	Body	Body Control Module Station Wagon						V	V	V						V				V	V	V																																				
D	2014	CTS	Body	Auxiliary Body Control Module																																																								
D	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
D	2014	CTS	Body	Passenger Presence Module																										V					V																									
D	2014	CTS	Body	Pedestrian Impact Detection Module																																																								
D	2014	CTS	Body	Instrument Cluster																																																								
D	2014	CTS	Body	Headlamp Control Module																																																								
D	2014	CTS	Body	Radio																																																								
D	2014	CTS	Body	Amplifier																																																								
D	2014	CTS	Body	Television Antenna Module																																																								
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
D	2014	CTS	Body	HVAC Control Module																																									V	V														
D	2014	CTS	Body	Driver Door Switch Panel Control Module																	V																																							
D	2014	CTS	Body	Passenger Door Switch Panel Control Module																																																								
D	2014	CTS	Body	Liftgate Control Module																																																								
D	2014	CTS	Body	Seat Memory Control Module																																					V	V																		
D	2014	CTS	Body	Right Side Object Detection Control Module																																								V	V															
D	2014	CTS	Body	Left Side Object Detection Control Module																																								V	V															
D	2014	CTS	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)										V			V																																											
D	2014	CTS	Body	Remote Control Keyless Type Standard Range (ATG)																																																								
D	2014	CTS	Body	Parking Assist Control Module																																V																								
D	2014	CTS	Body	Theft Deterrent Module										V																																														
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																								
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																								
D	2015	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																								
D	2015	CTS	Powertrain	Chassis Control Module																																																								
D	2015	CTS	Powertrain	Transfer Case Control Module																																																								
D	2015	CTS	Chassis	Electronic Brake Control Module					V																																																			
D	2015	CTS	Chassis	Parking Brake Control Module																																																								
D	2015	CTS	Chassis	Suspension Control Module																																																								
D	2015	CTS	Body	Body Control Module Coupe						V	V	V						V					V	V																																				
D	2015	CTS	Body	Body Control Module Station Wagon						V	V	V						V				V	V	V																																				
D	2015	CTS	Body	Auxiliary Body Control Module																																																								
D	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
D	2015	CTS	Body	Passenger Presence Module																										V					V																									
D	2015	CTS	Body	Pedestrian Impact Detection Module																																																								
D	2015	CTS	Body	Instrument Cluster																																																								
D	2015	CTS	Body	Headlamp Control Module																																																								
D	2015	CTS	Body	Radio																																																								
D	2015	CTS	Body	Amplifier																																																								
D	2015	CTS	Body	Television Antenna Module																																																								
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
D	2015	CTS	Body	HVAC Control Module																																									V	V														
D	2015	CTS	Body	Driver Door Switch Panel Control Module																	V																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2015	CTS	Body	Passenger Door Switch Panel Control Module																																																									
D	2015	CTS	Body	Liftgate Control Module																																																										
D	2015	CTS	Body	Seat Memory Control Module																																					V	V																				
D	2015	CTS	Body	Right Side Object Detection Control Module																																								V	V																
D	2015	CTS	Body	Left Side Object Detection Control Module																																								V	V																
D	2015	CTS	Body	Remote Control Door Lock Receiver										V			V																																												
D	2015	CTS	Body	Parking Assist Control Module																																V																											
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2004	(KD)Deville	Body	Amplifier (Delco)																																																										
K	2004	(KD)Deville	Body	CD Changer																																																										
K	2004	(KD)Deville	Body	Dash Integration Module																																																										
K	2004	(KD)Deville	Body	Digital Radio Receiver																																																										
K	2004	(KD)Deville	Body	Driver Door Switch																																																										
K	2004	(KD)Deville	Body	Driver Door Module																																																										
K	2004	(KD)Deville	Body	Passenger Door Module																																																										
K	2004	(KD)Deville	Body	Left Rear Door Module																																																										
K	2004	(KD)Deville	Body	Right Rear Door Module																																																										
K	2004	(KD)Deville	Body	Instrument Panel Cluster																																																										
K	2004	(KD)Deville	Body	Instrument Panel Module																																												V															
K	2004	(KD)Deville	Body	Memory Seat Module																																																										
K	2004	(KD)Deville	Body	Navigation Radio																																																										
K	2004	(KD)Deville	Body	Radio																																																										
K	2004	(KD)Deville	Body	Rear Climate Control Panel																																												V															
K	2004	(KD)Deville	Body	Rear Integration Module																																																										
K	2004	(KD)Deville	Body	Remote Function Actuation																																																										
K	2004	(KD)Deville	Body	Supplemental Inflatable Restraint																																																										
K	2004	(KD)Deville	Body	Tilt Telescope Module																																																										
K	2004	(KD)Deville	Body	Vehicle Theft Deterrent																																																										
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2004	(KE)DHS	Body	Amplifier (Bose)																																																										
K	2004	(KE)DHS	Body	CD Changer																																																										
K	2004	(KE)DHS	Body	Dash Integration Module																																																										
K	2004	(KE)DHS	Body	Digital Radio Receiver																																																										
K	2004	(KE)DHS	Body	Driver Door Switch																																																										
K	2004	(KE)DHS	Body	Driver Door Module																																																										
K	2004	(KE)DHS	Body	Passenger Door Module																																																										
K	2004	(KE)DHS	Body	Left Rear Door Module																																																										
K	2004	(KE)DHS	Body	Right Rear Door Module																																																										
K	2004	(KE)DHS	Body	Instrument Panel Cluster																																																										
K	2004	(KE)DHS	Body	Instrument Panel Module																																												V															
K	2004	(KE)DHS	Body	Memory Seat Module																																																										
K	2004	(KE)DHS	Body	Navigation Radio																																																										
K	2004	(KE)DHS	Body	Radio																																																										
K	2004	(KE)DHS	Body	Rear Climate Control Panel																																										V															
K	2004	(KE)DHS	Body	Rear Integration Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2004	(KE)DHS	Body	Remote Function Actuation																																																										
K	2004	(KE)DHS	Body	Supplemental Inflatable Restraint																																																										
K	2004	(KE)DHS	Body	Tilt Telescope Module																																																										
K	2004	(KE)DHS	Body	Vehicle Theft Deterrent																																																										
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2004	(KF)DTS	Body	Amplifier (Bose)																																																										
K	2004	(KF)DTS	Body	CD Changer																																																										
K	2004	(KF)DTS	Body	Dash Integration Module																																																										
K	2004	(KF)DTS	Body	Digital Radio Receiver																																																										
K	2004	(KF)DTS	Body	Driver Door Switch																																																										
K	2004	(KF)DTS	Body	Driver Door Module																																																										
K	2004	(KF)DTS	Body	Passenger Door Module																																																										
K	2004	(KF)DTS	Body	Left Rear Door Module																																																										
K	2004	(KF)DTS	Body	Right Rear Door Module																																																										
K	2004	(KF)DTS	Body	Instrument Panel Cluster																																																										
K	2004	(KF)DTS	Body	Instrument Panel Module																																													V														
K	2004	(KF)DTS	Body	Memory Seat Module																																																										
K	2004	(KF)DTS	Body	Navigation Radio																																																										
K	2004	(KF)DTS	Body	Radio																																																										
K	2004	(KF)DTS	Body	Rear Climate Control Panel																																													V														
K	2004	(KF)DTS	Body	Rear Integration Module																																																										
K	2004	(KF)DTS	Body	Remote Function Actuation																																																										
K	2004	(KF)DTS	Body	Supplemental Inflatable Restraint																																																										
K	2004	(KF)DTS	Body	Tilt Telescope Module																																																										
K	2004	(KF)DTS	Body	Vehicle Theft Deterrent																																																										
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2004	(KS)Seville SLS	Body	Amplifier (Bose)																																																										
K	2004	(KS)Seville SLS	Body	Amplifier (Delco)																																																										
K	2004	(KS)Seville SLS	Body	CD Changer																																																										
K	2004	(KS)Seville SLS	Body	Dash Integration Module																																																										
K	2004	(KS)Seville SLS	Body	Digital Radio Receiver																																																										
K	2004	(KS)Seville SLS	Body	Driver Door Module																																																										
K	2004	(KS)Seville SLS	Body	Instrument Panel Cluster																																																										
K	2004	(KS)Seville SLS	Body	Instrument Panel Module																																													V														
K	2004	(KS)Seville SLS	Body	Memory Seat Module																																																										
K	2004	(KS)Seville SLS	Body	Navigation Radio																																																										
K	2004	(KS)Seville SLS	Body	Radio																																																										
K	2004	(KS)Seville SLS	Body	Rear Integration Module																																																										
K	2004	(KS)Seville SLS	Body	Remote Function Actuation																																																										
K	2004	(KS)Seville SLS	Body	Supplemental Inflatable Restraint																																																										
K	2004	(KS)Seville SLS	Body	Tilt Telescope Module																																																										
K	2004	(KS)Seville SLS	Body	Vehicle Theft Deterrent																																																										
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																								
K	2004	(KY)Seville STS	Body	Amplifier (Bose)																																																								
K	2004	(KY)Seville STS	Body	Amplifier (Delco)																																																								
K	2004	(KY)Seville STS	Body	CD Changer																																																								
K	2004	(KY)Seville STS	Body	Dash Integration Module																																																								
K	2004	(KY)Seville STS	Body	Digital Radio Receiver																																																								
K	2004	(KY)Seville STS	Body	Driver Door Module																																																								
K	2004	(KY)Seville STS	Body	Instrument Panel Cluster																																																								
K	2004	(KY)Seville STS	Body	Instrument Panel Module																																																								
K	2004	(KY)Seville STS	Body	Memory Seat Module																																																								
K	2004	(KY)Seville STS	Body	Navigation Radio																																																								
K	2004	(KY)Seville STS	Body	Radio																																																								
K	2004	(KY)Seville STS	Body	Rear Integration Module																																																								
K	2004	(KY)Seville STS	Body	Remote Function Actuation																																																								
K	2004	(KY)Seville STS	Body	Supplemental Inflatable Restraint																																																								
K	2004	(KY)Seville STS	Body	Tilt Telescope Module																																																								
K	2004	(KY)Seville STS	Body	Vehicle Theft Deterrent																																																								
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																								
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																								
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																								
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																								
K	2005	(KD)Deville	Body	Amplifier (Delco)																																																								
K	2005	(KD)Deville	Body	CD Changer																																																								
K	2005	(KD)Deville	Body	Dash Integration Module																																																								
K	2005	(KD)Deville	Body	Digital Radio Receiver																																																								
K	2005	(KD)Deville	Body	Driver Door Switch																																																								
K	2005	(KD)Deville	Body	Driver Door Module																																																								
K	2005	(KD)Deville	Body	Passenger Door Module																																																								
K	2005	(KD)Deville	Body	Left Rear Door Module																																																								
K	2005	(KD)Deville	Body	Right Rear Door Module																																																								
K	2005	(KD)Deville	Body	Instrument Panel Cluster																																																								
K	2005	(KD)Deville	Body	Instrument Panel Module																																																								
K	2005	(KD)Deville	Body	Memory Seat Module																																																								
K	2005	(KD)Deville	Body	Navigation Radio																																																								
K	2005	(KD)Deville	Body	Radio																																																								
K	2005	(KD)Deville	Body	Rear Climate Control Panel																																																								
K	2005	(KD)Deville	Body	Rear Integration Module																																																								
K	2005	(KD)Deville	Body	Remote Function Actuation																																																								
K	2005	(KD)Deville	Body	Supplemental Inflatable Restraint																																																								
K	2005	(KD)Deville	Body	Tilt Telescope Module																																																								
K	2005	(KD)Deville	Body	Vehicle Theft Deterrent																																																								
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																								
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																								
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																								
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																								
K	2005	(KE)DHS	Body	Amplifier (Bose)																																																								
K	2005	(KE)DHS	Body	CD Changer																																																								
K	2005	(KE)DHS	Body	Dash Integration Module																																																								
K	2005	(KE)DHS	Body	Digital Radio Receiver																																																								
K	2005	(KE)DHS	Body	Driver Door Switch																																																								
K	2005	(KE)DHS	Body	Driver Door Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2005	(KE)DHS	Body	Passenger Door Module																																																								
K	2005	(KE)DHS	Body	Left Rear Door Module																																																								
K	2005	(KE)DHS	Body	Right Rear Door Module																																																								
K	2005	(KE)DHS	Body	Instrument Panel Cluster																																																								
K	2005	(KE)DHS	Body	Instrument Panel Module																																																								
K	2005	(KE)DHS	Body	Memory Seat Module																																																								
K	2005	(KE)DHS	Body	Navigation Radio																																																								
K	2005	(KE)DHS	Body	Radio																																																								
K	2005	(KE)DHS	Body	Rear Climate Control Panel																																																								
K	2005	(KE)DHS	Body	Rear Integration Module																																																								
K	2005	(KE)DHS	Body	Remote Function Actuation																																																								
K	2005	(KE)DHS	Body	Supplemental Inflatable Restraint																																																								
K	2005	(KE)DHS	Body	Tilt Telescope Module																																																								
K	2005	(KE)DHS	Body	Vehicle Theft Deterrent																																																								
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																								
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																								
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																								
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																								
K	2005	(KF)DTS	Body	Amplifier (Bose)																																																								
K	2005	(KF)DTS	Body	CD Changer																																																								
K	2005	(KF)DTS	Body	Dash Integration Module																																																								
K	2005	(KF)DTS	Body	Digital Radio Receiver																																																								
K	2005	(KF)DTS	Body	Driver Door Switch																																																								
K	2005	(KF)DTS	Body	Driver Door Module																																																								
K	2005	(KF)DTS	Body	Passenger Door Module																																																								
K	2005	(KF)DTS	Body	Left Rear Door Module																																																								
K	2005	(KF)DTS	Body	Right Rear Door Module																																																								
K	2005	(KF)DTS	Body	Instrument Panel Cluster																																																								
K	2005	(KF)DTS	Body	Instrument Panel Module																																																								
K	2005	(KF)DTS	Body	Memory Seat Module																																																								
K	2005	(KF)DTS	Body	Navigation Radio																																																								
K	2005	(KF)DTS	Body	Radio																																																								
K	2005	(KF)DTS	Body	Rear Climate Control Panel																																																								
K	2005	(KF)DTS	Body	Rear Integration Module																																																								
K	2005	(KF)DTS	Body	Remote Function Actuation																																																								
K	2005	(KF)DTS	Body	Supplemental Inflatable Restraint																																																								
K	2005	(KF)DTS	Body	Tilt Telescope Module																																																								
K	2005	(KF)DTS	Body	Vehicle Theft Deterrent																																																								
K	2006	ALL	Powertrain	Engine Control Module																																																								
K	2006	ALL	Powertrain	Automatic Transaxle																																																								
K	2006	ALL	Chassis	Antilock Brake System																																																								
K	2006	ALL	Body	Amplifier (Bose)																																																								
K	2006	ALL	Body	Aux. HVAC Control Module																																																								
K	2006	ALL	Body	Body Control Module																																																								
K	2006	ALL	Body	Digital Radio Receiver																																																								
K	2006	ALL	Body	Distance Sensing Cruise Control																																																								
K	2006	ALL	Body	Driver Door Switch																																																								
K	2006	ALL	Body	Driver Position Module																																																								
K	2006	ALL	Body	HVAC Control Module																																																								
K	2006	ALL	Body	Instrument Panel Cluster																																																								
K	2006	ALL	Body	Park Assist Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2006	ALL	Body	Passenger Door Switch																																																								
K	2006	ALL	Body	Passenger Presence System																																																								
K	2006	ALL	Body	Radio																																																								
K	2006	ALL	Body	Rear Heated Seat Module																																																								
K	2006	ALL	Body	Remote Control Door Lock Receiver																																																								
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2006	ALL	Body	Theft Deterrent Module																																																								
K	2006	ALL	Body	TV Antenna Module																																																								
K	2006	ALL	Body	Vehicle Comm. Interface Module																																	V																							
K	2007	ALL	Powertrain	Engine Control Module																																																								
K	2007	ALL	Powertrain	Transmission Control Module																																																								
K	2007	ALL	Chassis	Electronic Brake Control Module																																																								
K	2007	ALL	Body	Amplifier (Bose)																																																								
K	2007	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																								
K	2007	ALL	Body	Body Control Module																																																								
K	2007	ALL	Body	Digital Radio Receiver																																																								
K	2007	ALL	Body	Distance Sensing Cruise Control																																																								
K	2007	ALL	Body	Driver Door Switch																																																								
K	2007	ALL	Body	Driver Position Module																																																								
K	2007	ALL	Body	CJ2 Dual Zone HVAC Auto																																										V														
K	2007	ALL	Body	CJ4 Tri Zone HVAC Auto																																										V														
K	2007	ALL	Body	Inside Rear View Mirror Module																																																								
K	2007	ALL	Body	Instrument Panel Cluster																																																								
K	2007	ALL	Body	Park Assist Module																																																								
K	2007	ALL	Body	Passenger Door Switch																																																								
K	2007	ALL	Body	Passenger Presence System																																																								
K	2007	ALL	Body	Radio																																																								
K	2007	ALL	Body	Rear Heated Seat Module																																																								
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2007	ALL	Body	Theft Deterrent Module																																																								
K	2007	ALL	Body	TV Antenna Module																																																								
K	2007	ALL	Body	Vehicle Comm. Interface Module																																	V																							
K	2008	ALL	Powertrain	Engine Control Module																																																								
K	2008	ALL	Powertrain	Transmission Control Module																																																								
K	2008	ALL	Chassis	Electronic Brake Control Module																																																								
K	2008	ALL	Body	Amplifier (Bose)																																																								
K	2008	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																								
K	2008	ALL	Body	Body Control Module																																																								
K	2008	ALL	Body	Digital Radio Receiver																																																								
K	2008	ALL	Body	Distance Sensing Cruise Control																																																								
K	2008	ALL	Body	Driver Door Switch																																																								
K	2008	ALL	Body	Driver Position Module																																																								
K	2008	ALL	Body	CJ2 Dual Zone HVAC Auto																																										V														
K	2008	ALL	Body	CJ4 Tri Zone HVAC Auto																																										V														
K	2008	ALL	Body	Inside Rear View Mirror Module																																																								
K	2008	ALL	Body	Instrument Panel Cluster																																																								
K	2008	ALL	Body	Left Side Object Detection Module																																																								
K	2008	ALL	Body	Park Assist Module																																																								
K	2008	ALL	Body	Passenger Door Switch																																																								
K	2008	ALL	Body	Passenger Presence System																																																								
K	2008	ALL	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2008	ALL	Body	Rear Heated Seat Module																																																									
K	2008	ALL	Body	Right Side Object Detection Module																																																									
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2008	ALL	Body	Theft Deterrent Module																																																									
K	2008	ALL	Body	TV Antenna Module																																																									
K	2008	ALL	Body	Vehicle Comm. Interface Module																																V																										
K	2008	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																									
K	2009	ALL	Powertrain	Engine Control Module																																																									
K	2009	ALL	Powertrain	Transmission Control Module																																																									
K	2009	ALL	Chassis	Electronic Brake Control Module																																																									
K	2009	ALL	Body	Amplifier (Bose)																																																									
K	2009	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																									
K	2009	ALL	Body	Body Control Module																																																									
K	2009	ALL	Body	Digital Radio Receiver																																																									
K	2009	ALL	Body	Distance Sensing Cruise Control																																																									
K	2009	ALL	Body	Driver Door Switch																																																									
K	2009	ALL	Body	Driver Position Module																																																									
K	2009	ALL	Body	CJ2 Dual Zone HVAC Auto																																												V														
K	2009	ALL	Body	CJ4 Tri Zone HVAC Auto																																												V														
K	2009	ALL	Body	Inside Rear View Mirror Module																																																									
K	2009	ALL	Body	Instrument Panel Cluster																																																									
K	2009	ALL	Body	Left Side Object Detection Module																																																									
K	2009	ALL	Body	Park Assist Module																																																									
K	2009	ALL	Body	Passenger Door Switch																																																									
K	2009	ALL	Body	Passenger Presence System																																																									
K	2009	ALL	Body	Radio																																																									
K	2009	ALL	Body	Rear Heated Seat Module																																																									
K	2009	ALL	Body	Right Side Object Detection Module																																																									
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2009	ALL	Body	Theft Deterrent Module																																																									
K	2009	ALL	Body	TV Antenna Module																																																									
K	2009	ALL	Body	Vehicle Comm. Interface Module																																V																										
K	2009	ALL	Body	Vehicle Comm. Interface Module																																V		V																								
K	2009	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																									
K	2010	ALL	Powertrain	Engine Control Module																																																									
K	2010	ALL	Powertrain	Transmission Control Module																																																									
K	2010	ALL	Chassis	Electronic Brake Control Module																																																									
K	2010	ALL	Body	Amplifier (Bose)																																																									
K	2010	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																									
K	2010	ALL	Body	Body Control Module																																																									
K	2010	ALL	Body	Digital Radio Receiver																																																									
K	2010	ALL	Body	Distance Sensing Cruise Control																																																									
K	2010	ALL	Body	Driver Door Switch																																																									
K	2010	ALL	Body	Driver Position Module																																																									
K	2010	ALL	Body	CJ2 Dual Zone HVAC Auto																																												V														
K	2010	ALL	Body	CJ4 Tri Zone HVAC Auto																																												V														
K	2010	ALL	Body	Inside Rear View Mirror Module																																																									
K	2010	ALL	Body	Instrument Panel Cluster																																																									
K	2010	ALL	Body	Left Side Object Detection Module																																																									
K	2010	ALL	Body	Park Assist Module																																																									
K	2010	ALL	Body	Passenger Door Switch																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2010	ALL	Body	Passenger Presence System																																																										
K	2010	ALL	Body	Radio																																																										
K	2010	ALL	Body	Rear Heated Seat Module																																																										
K	2010	ALL	Body	Right Side Object Detection Module																																																										
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2010	ALL	Body	Theft Deterrent Module																																																										
K	2010	ALL	Body	TV Antenna Module																																																										
K	2010	ALL	Body	Vehicle Comm. Interface Module																																	V		V																							
K	2010	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																										
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Engine Control Module																																																										
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Transmission Control Module																																																										
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Engine Control Module																																																										
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Transmission Control Module																																																										
K	2011	ALL	Chassis	Electronic Brake Control Module																																																										
K	2011	ALL	Body	Amplifier (Bose)																																																										
K	2011	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																										
K	2011	ALL	Body	Body Control Module																																																										
K	2011	ALL	Body	Digital Radio Receiver																																																										
K	2011	ALL	Body	Distance Sensing Cruise Control																																																										
K	2011	ALL	Body	Driver Door Switch																																																										
K	2011	ALL	Body	Driver Position Module																																																										
K	2011	ALL	Body	CJ2 Dual Zone HVAC Auto																																													V													
K	2011	ALL	Body	CJ4 Tri Zone HVAC Auto																																													V													
K	2011	ALL	Body	Inside Rear View Mirror Module																																																										
K	2011	ALL	Body	Instrument Panel Cluster																																																										
K	2011	ALL	Body	Left Side Object Detection Module																																																										
K	2011	ALL	Body	Park Assist Module																																																										
K	2011	ALL	Body	Passenger Door Switch																																																										
K	2011	ALL	Body	Passenger Presence System																																																										
K	2011	ALL	Body	Radio																																																										
K	2011	ALL	Body	Rear Heated Seat Module																																																										
K	2011	ALL	Body	Right Side Object Detection Module																																																										
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2011	ALL	Body	Theft Deterrent Module																																																										
K	2011	ALL	Body	TV Antenna Module																																																										
K	2011	ALL	Body	Vehicle Comm. Interface Module																																	V		V																							
K	2011	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																										
K	2016	CT6	Powertrain	(X) 2.0L LTG Engine Control Module																				V																																						
K	2016	CT6	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
K	2016	CT6	Powertrain	(6) 3.0L LGW Engine Control Module																				V																																						
K	2016	CT6	Powertrain	(6) 3.0L LGW Transmission Control Module																																																										
K	2016	CT6	Powertrain	(S) 3.6L LGX Engine Control Module																				V																																						
K	2016	CT6	Powertrain	(S) 3.6L LGX Transmission Control Module																																																										
K	2016	CT6	Powertrain	Transfer Case Control Module																																																										
K	2016	CT6	Chassis	Electronic Brake Control Module				V																																																						
K	2016	CT6	Chassis	Brake Booster Control Module																																																										
K	2016	CT6	Chassis	Power Steering Control Module			V																																																							
K	2016	CT6	Chassis	Rear Wheel Steering Control Module																																																										
K	2016	CT6	Chassis	Suspension Control Module																																																										
K	2016	CT6	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																									V									
K	2016	CT6	Body	Serial Data Gateway Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2016	CT6	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
K	2016	CT6	Body	Passenger Presence Module																																V																									
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Left																																																								
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Right																																																								
K	2016	CT6	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																V																									
K	2016	CT6	Body	Instrument Cluster Full Screen Display (UDV)																																V																									
K	2016	CT6	Body	Radio Controls																																																								
K	2016	CT6	Body	HVAC Controls																																																								
K	2016	CT6	Body	Active Safety Control Module																																																								
K	2016	CT6	Body	Video Processing Control Module																																																								
K	2016	CT6	Body	Headlamp Control Module																																																								
K	2016	CT6	Body	Trailer Interface Control Module																																V																									
K	2016	CT6	Body	Radio																																																								
K	2016	CT6	Body	Amplifier																																																								
K	2016	CT6	Body	Infotainment Control Touchpad																																																								
K	2016	CT6	Body	Human Machine Interface Control Module																																																								
K	2016	CT6	Body	Navigation Control Module																																																								
K	2016	CT6	Body	Telematics Communication Interface Control Module																																	V	V	V																						
K	2016	CT6	Body	HVAC Control Module																														V														V	V		V									
K	2016	CT6	Body	Liftgate Control Module																																																								
K	2016	CT6	Body	Seat Memory Control Module - Passenger																																																								
K	2016	CT6	Body	Seat Memory Control Module - Left Rear																																																								
K	2016	CT6	Body	Seat Memory Control Module - Driver																																																								
K	2016	CT6	Body	Seat Memory Control Module - Right Rear																																																								
K	2016	CT6	Body	Keyless Entry Control Module																																																								
K	2016	CT6	Body	Left Side Object Detection Control Module																																																								
K	2016	CT6	Body	Parking Assist Control Module																																V																									
K	2016	CT6	Body	Frontview Camera Module																																																								
K	2016	CT6	Body	Long Range Radar Sensor Module																																																								
K	2016	CT6	Body	Left Front Short Range Radar Sensor Module																																																								
K	2016	CT6	Body	Right Front Short Range Radar Sensor Module																																																								
K	2016	CT6	Body	Rear Short Range Radar Sensor Module																																																								
K	2016	CT6	Body	Night Vision Camera Control Module																																																								
R	2014	ELR	Powertrain	Engine Control Module																																																								
R	2014	ELR	Powertrain	Trasmission Control Module																																																								
R	2014	ELR	Powertrain	Chassis Control Module																																																				V	V		
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module										V																																	V										V	V
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module 2																																											V											
R	2014	ELR	Powertrain	Drive Motor Control Module 1																																																							
R	2014	ELR	Powertrain	Drive Motor Control Module 2																																																							
R	2014	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																							
R	2014	ELR	Chassis	Electronic Brake Control Module																																																							
R	2014	ELR	Chassis	Distance Sensing Cruise Control Module																																																							
R	2014	ELR	Chassis	Parking Brake Control Module																																																							
R	2014	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																							
R	2014	ELR	Chassis	Power Steering Control Module	V	V																							V	V	V	V	V	V	V																									
R	2014	ELR	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
R	2014	ELR	Chassis	Suspension Control Module																																																							
R	2014	ELR	Body	Body Control Module						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V	V																						V							
R	2014	ELR	Body	Pedestrian Impact Detection Module																																																							
R	2014	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2014	ELR	Body	Passenger Presence Module																																V																								
R	2014	ELR	Body	Instrument Cluster																																	V																						
R	2014	ELR	Body	Radio/HVAC Control																																																							
R	2014	ELR	Body	Radio																																																							
R	2014	ELR	Body	Amplifier																																																							
R	2014	ELR	Body	Human Machine Interface Control Module																																																							
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																			
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
R	2014	ELR	Body	HVAC Control Module																														V												V	V	V	V	V									
R	2014	ELR	Body	Electric A/C Compressor Control Module																																																							
R	2014	ELR	Body	Coolant Heater Control Module																																																							
R	2014	ELR	Body	Seat Memory Control Module - Driver																																																							
R	2014	ELR	Body	Keyless Entry Control Module																																																							
R	2014	ELR	Body	Right Side Object Detection Control Module																																																							
R	2014	ELR	Body	Left Side Object Detection Control Module																																																							
R	2014	ELR	Body	Parking Assist Control Module																																	V																						
R	2014	ELR	Body	Frontview Camera Module																																																							
R	2014	ELR	Body	Steering Column Lock Control Module																																																							
R	2014	ELR	Body	Battery Charger Control Module																																																							
R	2014	ELR	Body	Battery Energy Control Module																																																							
R	2015	ELR	Powertrain	Engine Control Module																																																							
R	2015	ELR	Powertrain	Trasmission Control Module																																																							
R	2015	ELR	Powertrain	Chassis Control Module																																																			V	V		
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module										V																																	V										V	V
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module 2																																											V											
R	2015	ELR	Powertrain	Drive Motor Control Module 1																																																						
R	2015	ELR	Powertrain	Drive Motor Control Module 2																																																						
R	2015	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																						
R	2015	ELR	Chassis	Electronic Brake Control Module																																																						
R	2015	ELR	Chassis	Distance Sensing Cruise Control Module																																																						
R	2015	ELR	Chassis	Parking Brake Control Module																																																						
R	2015	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																						
R	2015	ELR	Chassis	Power Steering Control Module	V	V																																																				
R	2015	ELR	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
R	2015	ELR	Chassis	Suspension Control Module																																																						
R	2015	ELR	Body	Body Control Module						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																							V							
R	2015	ELR	Body	Pedestrian Impact Detection Module																																																						
R	2015	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
R	2015	ELR	Body	Passenger Presence Module																																V																						
R	2015	ELR	Body	Instrument Cluster																																	V																						
R	2015	ELR	Body	Radio/HVAC Control																																																						
R	2015	ELR	Body	Headlamp Control Module																																																						
R	2015	ELR	Body	Radio																																																						
R	2015	ELR	Body	Amplifier																																																						
R	2015	ELR	Body	Human Machine Interface Control Module																																																						
R	2015	ELR	Body	Telematics Communication Interface Control Module																																	V	V	V																				
R	2015	ELR	Body	HVAC Control Module																														V												V	V	V	V	V									
R	2015	ELR	Body	Electric A/C Compressor Control Module																																																						
R	2015	ELR	Body	Coolant Heater Control Module																																																						
R	2015	ELR	Body	Seat Memory Control Module - Driver																																																						
R	2015	ELR	Body	Keyless Entry Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2015	ELR	Body	Right Side Object Detection Control Module																																																									
R	2015	ELR	Body	Left Side Object Detection Control Module																																																										
R	2015	ELR	Body	Parking Assist Control Module																																V																										
R	2015	ELR	Body	Frontview Camera Module																																																									
R	2015	ELR	Body	Steering Column Lock Control Module																																																										
R	2015	ELR	Body	Battery Charger Control Module																																																										
R	2015	ELR	Body	Battery Energy Control Module																																																										
R	2016	ELR	Powertrain	Engine Control Module																																																										
R	2016	ELR	Powertrain	Trasmission Control Module																																																										
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module										V																																		V									V	V
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module 2																																												V										
R	2016	ELR	Powertrain	Drive Motor Control Module 1																																																									
R	2016	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2016	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2016	ELR	Chassis	Electronic Brake Control Module																																																										
R	2016	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2016	ELR	Chassis	Parking Brake Control Module																																																										
R	2016	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2016	ELR	Chassis	Power Steering Control Module	V	V																																																								
R	2016	ELR	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
R	2016	ELR	Chassis	Suspension Control Module																																																										
R	2016	ELR	Body	Body Control Module						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																								V								
R	2016	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2016	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
R	2016	ELR	Body	Passenger Presence Module																																V																										
R	2016	ELR	Body	Instrument Cluster																																	V																									
R	2016	ELR	Body	Radio/HVAC Control																																																										
R	2016	ELR	Body	Headlamp Control Module																																																										
R	2016	ELR	Body	Radio																																																										
R	2016	ELR	Body	Amplifier																																																										
R	2016	ELR	Body	Human Machine Interface Control Module																																																										
R	2016	ELR	Body	Telematics Communication Interface Control Module																																	V	V	V																							
R	2016	ELR	Body	HVAC Control Module																														V													V	V	V	V	V										
R	2016	ELR	Body	Electric A/C Compressor Control Module																																																										
R	2016	ELR	Body	Coolant Heater Control Module																																																										
R	2016	ELR	Body	Seat Memory Control Module - Driver																																																										
R	2016	ELR	Body	Keyless Entry Control Module																																																										
R	2016	ELR	Body	Left Side Object Detection Control Module																																																										
R	2016	ELR	Body	Parking Assist Control Module																																	V																										
R	2016	ELR	Body	Frontview Camera Module																																																										
R	2016	ELR	Body	Steering Column Lock Control Module																																																										
R	2016	ELR	Body	Battery Charger Control Module																																																										
R	2016	ELR	Body	Battery Energy Control Module																																																										
Y	2004	ALL	Powertrain	Engine Control Module																																																										
Y	2004	ALL	Powertrain	Automatic Transmission																																																										
Y	2004	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2004	ALL	Chassis	Electronic Suspension Control																																																										
Y	2004	ALL	Chassis	Steering Wheel and Column																																																										
Y	2004	ALL	Body	Amplifier (Bose)																																																										
Y	2004	ALL	Body	Body Control Module																																																										
Y	2004	ALL	Body	CD Changer																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Y	2004	ALL	Body	Digital Radio Receiver																																																												
Y	2004	ALL	Body	Distance Sensing Cruise Control																																																												
Y	2004	ALL	Body	Driver Door Module																																																												
Y	2004	ALL	Body	Driver Door Switch																																																												
Y	2004	ALL	Body	Driver Position Module																																																												
Y	2004	ALL	Body	Folding Top Module																																																												
Y	2004	ALL	Body	Head Up Display																																																												
Y	2004	ALL	Body	HVAC Control Module																																													V															
Y	2004	ALL	Body	Instrument Panel Cluster																																																												
Y	2004	ALL	Body	Navigation Radio																																																												
Y	2004	ALL	Body	Passenger Door Module																																																												
Y	2004	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2004	ALL	Body	Steering Column Lock Module																																																												
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2005	ALL	Powertrain	Engine Control Module																																																												
Y	2005	ALL	Powertrain	Automatic Transmission																																																												
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2005	ALL	Chassis	Electronic Suspension Control																																																												
Y	2005	ALL	Chassis	Steering Wheel and Column																																																												
Y	2005	ALL	Body	Amplifier (Bose)																																																												
Y	2005	ALL	Body	Body Control Module																																																												
Y	2005	ALL	Body	CD Changer																																																												
Y	2005	ALL	Body	Digital Radio Receiver																																																												
Y	2005	ALL	Body	Distance Sensing Cruise Control																																																												
Y	2005	ALL	Body	Driver Door Module																																																												
Y	2005	ALL	Body	Driver Door Switch																																																												
Y	2005	ALL	Body	Driver Position Module																																																												
Y	2005	ALL	Body	Folding Top Module																																																												
Y	2005	ALL	Body	Head Up Display																																																												
Y	2005	ALL	Body	HVAC Control Module																																													V															
Y	2005	ALL	Body	Instrument Panel Cluster																																																												
Y	2005	ALL	Body	Navigation Radio																																																												
Y	2005	ALL	Body	Passenger Door Module																																																												
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2005	ALL	Body	Steering Column Lock Module																																																												
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2006	(YV)XLR	Powertrain	Engine Control Module																																																												
Y	2006	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																												
Y	2006	(YV)XLR	Powertrain	Automatic Transmission																																																												
Y	2006	(YV)XLR	Chassis	Electronic Brake Control Module																																																												
Y	2006	(YV)XLR	Chassis	Electronic Suspension Control																																																												
Y	2006	(YV)XLR	Chassis	Steering Wheel and Column																																																												
Y	2006	(YV)XLR	Body	Amplifier (Bose)																																																												
Y	2006	(YV)XLR	Body	Body Control Module																																																												
Y	2006	(YV)XLR	Body	CD Changer																																																												
Y	2006	(YV)XLR	Body	Digital Radio Receiver																																																												
Y	2006	(YV)XLR	Body	Distance Sensing Cruise Control																																																												
Y	2006	(YV)XLR	Body	Driver Door Module																																																												
Y	2006	(YV)XLR	Body	Driver Door Switch																																																												
Y	2006	(YV)XLR	Body	Driver Position Module																																																												
Y	2006	(YV)XLR	Body	Folding Top Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Y	2006	(YV)XLR	Body	Headlamp Control Module																																																									
Y	2006	(YV)XLR	Body	Head Up Display																																																										
Y	2006	(YV)XLR	Body	HVAC Control Module																																												V													
Y	2006	(YV)XLR	Body	Instrument Panel Cluster																																																									
Y	2006	(YV)XLR	Body	Navigation Radio																																																										
Y	2006	(YV)XLR	Body	Passenger Door Module																																																										
Y	2006	(YV)XLR	Body	Remote Control Door Lock Receiver																																																										
Y	2006	(YV)XLR	Body	Steering Column Lock Module																																																										
Y	2006	(YV)XLR	Body	Supplemental Inflatable Restraint																																																										
Y	2006	(YX)XLR-V	Powertrain	Engine Control Module																																																										
Y	2006	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																										
Y	2006	(YX)XLR-V	Powertrain	Automatic Transmission																																																										
Y	2006	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																										
Y	2006	(YX)XLR-V	Chassis	Electronic Suspension Control																																																										
Y	2006	(YX)XLR-V	Chassis	Steering Wheel and Column																																																										
Y	2006	(YX)XLR-V	Body	Amplifier (Bose)																																																										
Y	2006	(YX)XLR-V	Body	Body Control Module																																																										
Y	2006	(YX)XLR-V	Body	CD Changer																																																										
Y	2006	(YX)XLR-V	Body	Digital Radio Receiver																																																										
Y	2006	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																										
Y	2006	(YX)XLR-V	Body	Driver Door Module																																																										
Y	2006	(YX)XLR-V	Body	Driver Door Switch																																																										
Y	2006	(YX)XLR-V	Body	Driver Position Module																																																										
Y	2006	(YX)XLR-V	Body	Folding Top Module																																																										
Y	2006	(YX)XLR-V	Body	Headlamp Control Module																																																										
Y	2006	(YX)XLR-V	Body	Head Up Display																																																										
Y	2006	(YX)XLR-V	Body	HVAC Control Module																																												V													
Y	2006	(YX)XLR-V	Body	Instrument Panel Cluster																																																										
Y	2006	(YX)XLR-V	Body	Navigation Radio																																																										
Y	2006	(YX)XLR-V	Body	Passenger Door Module																																																										
Y	2006	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																																										
Y	2006	(YX)XLR-V	Body	Steering Column Lock Module																																																										
Y	2006	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																										
Y	2007	(YV)XLR	Powertrain	Engine Control Module																																																										
Y	2007	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	(YV)XLR	Powertrain	Transmission Control Module																																																										
Y	2007	(YV)XLR	Chassis	Electronic Brake Control Module																																																										
Y	2007	(YV)XLR	Chassis	Electronic Suspension Control																																																										
Y	2007	(YV)XLR	Body	Amplifier (Bose)																																																										
Y	2007	(YV)XLR	Body	Body Control Module																																																										
Y	2007	(YV)XLR	Body	CD Changer																																																										
Y	2007	(YV)XLR	Body	Digital Radio Receiver																																																										
Y	2007	(YV)XLR	Body	Distance Sensing Cruise Control																																																										
Y	2007	(YV)XLR	Body	Driver Door Module																																																										
Y	2007	(YV)XLR	Body	Driver Door Switch																																																										
Y	2007	(YV)XLR	Body	Driver Position Module																																																										
Y	2007	(YV)XLR	Body	Folding Top Module																																																										
Y	2007	(YV)XLR	Body	Headlamp Control Module																																																										
Y	2007	(YV)XLR	Body	Head Up Display																																																										
Y	2007	(YV)XLR	Body	HVAC Control Module																																												V													
Y	2007	(YV)XLR	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Y	2007	(YV)XLR	Body	Navigation Radio																																																										
Y	2007	(YV)XLR	Body	Passenger Door Module																																																										
Y	2007	(YV)XLR	Body	Remote Control Door Lock Receiver																																																										
Y	2007	(YV)XLR	Body	Steering Column Lock Module																																																										
Y	2007	(YV)XLR	Body	Supplemental Inflatable Restraint																																																										
Y	2007	(YX)XLR-V	Powertrain	Engine Control Module																																																										
Y	2007	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	(YX)XLR-V	Powertrain	Transmission Control Module																																																										
Y	2007	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																										
Y	2007	(YX)XLR-V	Chassis	Electronic Suspension Control																																																										
Y	2007	(YX)XLR-V	Body	Amplifier (Bose)																																																										
Y	2007	(YX)XLR-V	Body	Body Control Module																																																										
Y	2007	(YX)XLR-V	Body	CD Changer																																																										
Y	2007	(YX)XLR-V	Body	Digital Radio Receiver																																																										
Y	2007	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																										
Y	2007	(YX)XLR-V	Body	Driver Door Module																																																										
Y	2007	(YX)XLR-V	Body	Driver Door Switch																																																										
Y	2007	(YX)XLR-V	Body	Driver Position Module																																																										
Y	2007	(YX)XLR-V	Body	Folding Top Module																																																										
Y	2007	(YX)XLR-V	Body	Headlamp Control Module																																																										
Y	2007	(YX)XLR-V	Body	Head Up Display																																																										
Y	2007	(YX)XLR-V	Body	HVAC Control Module																																												V														
Y	2007	(YX)XLR-V	Body	Instrument Panel Cluster																																																										
Y	2007	(YX)XLR-V	Body	Navigation Radio																																																										
Y	2007	(YX)XLR-V	Body	Passenger Door Module																																																										
Y	2007	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																																										
Y	2007	(YX)XLR-V	Body	Steering Column Lock Module																																																										
Y	2007	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2008	ALL	Chassis	Electronic Suspension Control																																																										
Y	2008	ALL	Body	Amplifier (Bose)																																																										
Y	2008	ALL	Body	Body Control Module																																																										
Y	2008	ALL	Body	CD Changer																																																										
Y	2008	ALL	Body	Digital Radio Receiver																																																										
Y	2008	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2008	ALL	Body	Driver Door Module																																																										
Y	2008	ALL	Body	Driver Door Switch																																																										
Y	2008	ALL	Body	Driver Position Module																																																										
Y	2008	ALL	Body	Folding Top Module																																																										
Y	2008	ALL	Body	Headlamp Control Module																																																										
Y	2008	ALL	Body	Head Up Display																																																										
Y	2008	ALL	Body	HVAC Control Module																																												V														
Y	2008	ALL	Body	Instrument Panel Cluster																																																										
Y	2008	ALL	Body	Navigation Radio																																																										
Y	2008	ALL	Body	Passenger Door Module																																																										
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Y	2008	ALL	Body	Steering Column Lock Module																																																								
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2008	ALL	Body	Vehicle Comm. Interface Module																																	V																							
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																								
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																								
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																								
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																								
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
Y	2009	ALL	Chassis	Electronic Brake Control Module																																																								
Y	2009	ALL	Chassis	Electronic Suspension Control																																																								
Y	2009	ALL	Body	Amplifier (Bose)																																																								
Y	2009	ALL	Body	Body Control Module																																																								
Y	2009	ALL	Body	CD Changer																																																								
Y	2009	ALL	Body	Digital Radio Receiver																																																								
Y	2009	ALL	Body	Distance Sensing Cruise Control																																																								
Y	2009	ALL	Body	Driver Door Module																																																								
Y	2009	ALL	Body	Driver Door Switch																																																								
Y	2009	ALL	Body	Driver Position Module																																																								
Y	2009	ALL	Body	Folding Top Module																																																								
Y	2009	ALL	Body	Headlamp Control Module																																																								
Y	2009	ALL	Body	Head Up Display																																																								
Y	2009	ALL	Body	HVAC Control Module																																											V													
Y	2009	ALL	Body	Instrument Panel Cluster																																																								
Y	2009	ALL	Body	Navigation Radio																																																								
Y	2009	ALL	Body	Passenger Door Module																																																								
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2009	ALL	Body	Steering Column Lock Module																																																								
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
1	2013	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
1	2013	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
1	2013	XTS	Powertrain	Fuel Pump Control Module																																																								
1	2013	XTS	Powertrain	Rear Differential Clutch Control Module																																																								
1	2013	XTS	Chassis	Electronic Brake Control Module					V																																																			
1	2013	XTS	Chassis	Parking Brake Control Module																																																								
1	2013	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																								
1	2013	XTS	Chassis	Power Steering Control Module																																																								
1	2013	XTS	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
1	2013	XTS	Chassis	Suspension Control Module																																																								
1	2013	XTS	Body	Body Control Module						V	V	V	V	V	V	V	V		V		V	V	V	V	V	V	V	V																								V								
1	2013	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
1	2013	XTS	Body	Passenger Presence Module																															V																									
1	2013	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																V																								
1	2013	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																V																								
1	2013	XTS	Body	Radio/HVAC Control																																																								
1	2013	XTS	Body	Active Safety Control Module																																																								
1	2013	XTS	Body	Headlamp Control Module																																																								
1	2013	XTS	Body	Radio																																																								
1	2013	XTS	Body	Amplifier																																																								
1	2013	XTS	Body	Human Machine Interface Control Module																																																								
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2013	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																															V													V	V		V								
1	2013	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																															V													V	V		V								
1	2013	XTS	Body	Seat Memory Control Module																																																							
1	2013	XTS	Body	Keyless Entry Control Module																																																						
1	2013	XTS	Body	Right Side Object Detection Control Module																																																						
1	2013	XTS	Body	Left Side Object Detection Control Module																																																						
1	2013	XTS	Body	Parking Assist Control Module																																V																							
1	2013	XTS	Body	Frontview Camera Module																																																						
1	2013	XTS	Body	Long Range Radar Sensor Module																																																						
1	2013	XTS	Body	Left Front Short Range Radar Sensor Module																																																						
1	2013	XTS	Body	Right Front Short Range Radar Sensor Module																																																						
1	2013	XTS	Body	Rear Short Range Radar Sensor Module																																																						
1	2014	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																				V																																			
1	2014	XTS	Powertrain	(8) 3.6L LF3 Chassis Control Module																																																						
1	2014	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																						
1	2014	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																			
1	2014	XTS	Powertrain	(3) 3.6L LFX Chassis Control Module																																																						
1	2014	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						
1	2014	XTS	Powertrain	Rear Differential Clutch Control Module																																																						
1	2014	XTS	Chassis	Electronic Brake Control Module					V																																																	
1	2014	XTS	Chassis	Parking Brake Control Module																																																						
1	2014	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																						
1	2014	XTS	Chassis	Power Steering Control Module																																																						
1	2014	XTS	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
1	2014	XTS	Chassis	Suspension Control Module																																																						
1	2014	XTS	Body	Body Control Module						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																									V						
1	2014	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
1	2014	XTS	Body	Passenger Presence Module																																V																							
1	2014	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																	V																						
1	2014	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																	V																						
1	2014	XTS	Body	Radio/HVAC Control																																																						
1	2014	XTS	Body	Active Safety Control Module																																																						
1	2014	XTS	Body	Headlamp Control Module																																																						
1	2014	XTS	Body	Radio																																																						
1	2014	XTS	Body	Amplifier																																																						
1	2014	XTS	Body	Media Disc Player																																																						
1	2014	XTS	Body	Human Machine Interface Control Module																																																						
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																		
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
1	2014	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																															V													V	V		V								
1	2014	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																															V													V	V		V								
1	2014	XTS	Body	Seat Memory Control Module - Passenger																																																						
1	2014	XTS	Body	Seat Memory Control Module - Driver																																																						
1	2014	XTS	Body	Keyless Entry Control Module																																																						
1	2014	XTS	Body	Right Side Object Detection Control Module																																																						
1	2014	XTS	Body	Left Side Object Detection Control Module																																																						
1	2014	XTS	Body	Parking Assist Control Module																																V																							
1	2014	XTS	Body	Frontview Camera Module																																																						
1	2014	XTS	Body	Long Range Radar Sensor Module																																																						
1	2014	XTS	Body	Left Front Short Range Radar Sensor Module																																																						
1	2014	XTS	Body	Right Front Short Range Radar Sensor Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2014	XTS	Body	Rear Short Range Radar Sensor Module																																																								
1	2015	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																				V																																				
1	2015	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																								
1	2015	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
1	2015	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
1	2015	XTS	Powertrain	Chassis Control Module																																																								
1	2015	XTS	Powertrain	Rear Differential Clutch Control Module																																																								
1	2015	XTS	Chassis	Electronic Brake Control Module				V																																																				
1	2015	XTS	Chassis	Parking Brake Control Module																																																								
1	2015	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																								
1	2015	XTS	Chassis	Power Steering Control Module																																																								
1	2015	XTS	Chassis	Steering Wheel Angle Sensor Module			V	V																																																				
1	2015	XTS	Chassis	Suspension Control Module																																																								
1	2015	XTS	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V	V	V																												V					
1	2015	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
1	2015	XTS	Body	Passenger Presence Module																				V											V																									
1	2015	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																V																								
1	2015	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																V																								
1	2015	XTS	Body	Radio/HVAC Control																																																								
1	2015	XTS	Body	Active Safety Control Module																																																								
1	2015	XTS	Body	Radio																																																								
1	2015	XTS	Body	Amplifier																																																								
1	2015	XTS	Body	Media Disc Player																																																								
1	2015	XTS	Body	Human Machine Interface Control Module																																																								
1	2015	XTS	Body	Telematics Communication Interface Control Module																																V	V	V																					
1	2015	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V		V										
1	2015	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																														V												V	V		V										
1	2015	XTS	Body	Seat Memory Control Module - Passenger																																																								
1	2015	XTS	Body	Seat Memory Control Module - Driver																																																								
1	2015	XTS	Body	Keyless Entry Control Module																																																								
1	2015	XTS	Body	Right Side Object Detection Control Module																																																								
1	2015	XTS	Body	Left Side Object Detection Control Module																																																								
1	2015	XTS	Body	Parking Assist Control Module GMLAN																																V																								
1	2015	XTS	Body	Parking Assist Control Module DID72History																																V																								
1	2015	XTS	Body	Frontview Camera Module																																																								
1	2015	XTS	Body	Long Range Radar Sensor Module																																																								
1	2015	XTS	Body	Left Front Short Range Radar Sensor Module																																																								
1	2015	XTS	Body	Right Front Short Range Radar Sensor Module																																																								
1	2015	XTS	Body	Rear Short Range Radar Sensor Module																																																								
1	2016	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																				V																																				
1	2016	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																								
1	2016	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
1	2016	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
1	2016	XTS	Powertrain	Chassis Control Module																																																								
1	2016	XTS	Powertrain	Rear Differential Clutch Control Module																																																								
1	2016	XTS	Chassis	Electronic Brake Control Module				V																																																				
1	2016	XTS	Chassis	Parking Brake Control Module																																																								
1	2016	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																								
1	2016	XTS	Chassis	Power Steering Control Module																																																								
1	2016	XTS	Chassis	Steering Wheel Angle Sensor Module			V	V																																																				
1	2016	XTS	Chassis	Suspension Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2016	XTS	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V	V																																
1	2016	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																									
1	2016	XTS	Body	Passenger Presence Module																																V																									
1	2016	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																	V																							
1	2016	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																	V																							
1	2016	XTS	Body	Radio/HVAC Control																																																								
1	2016	XTS	Body	Active Safety Control Module																																																								
1	2016	XTS	Body	Video Processing Control Module																																																								
1	2016	XTS	Body	Radio																																																								
1	2016	XTS	Body	Amplifier																																																								
1	2016	XTS	Body	Media Disc Player																																																								
1	2016	XTS	Body	Human Machine Interface Control Module																																																								
1	2016	XTS	Body	Telematics Communication Interface Control Module																																	V	V	V																						
1	2016	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V		V										
1	2016	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																														V												V	V		V										
1	2016	XTS	Body	Seat Memory Control Module - Passenger																																																								
1	2016	XTS	Body	Seat Memory Control Module - Driver																																																								
1	2016	XTS	Body	Keyless Entry Control Module																																																								
1	2016	XTS	Body	Right Side Object Detection Control Module																																																								
1	2016	XTS	Body	Left Side Object Detection Control Module																																																								
1	2016	XTS	Body	Parking Assist Control Module																																	V																							
1	2016	XTS	Body	Frontview Camera Module																																																								
1	2016	XTS	Body	Steering Column Lock Control Module																																																								
1	2016	XTS	Body	Long Range Radar Sensor Module																																																								
1	2016	XTS	Body	Left Front Short Range Radar Sensor Module																																																								
1	2016	XTS	Body	Right Front Short Range Radar Sensor Module																																																								
1	2016	XTS	Body	Rear Short Range Radar Sensor Module																																																								

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
A	2014	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2014	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2014	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2014	CTS	Body	Keyless Entry Control Module																																																										
A	2014	CTS	Body	Right Side Object Detection Control Module																																																										
A	2014	CTS	Body	Left Side Object Detection Control Module																																																										
A	2014	CTS	Body	Parking Assist Control Module																																																										
A	2014	CTS	Body	Frontview Camera Module																											V	V																													
A	2014	CTS	Body	Steering Column Lock Control Module																																																										
A	2014	CTS	Body	Long Range Radar Sensor Module																																																										
A	2014	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2014	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2014	CTS	Body	Rear Short Range Radar Sensor Module																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																											V															
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																											V															
A	2015	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																											V															
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																											V															
A	2015	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																											V															
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																											V															
A	2015	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2015	ATS	Powertrain	Transfer Case Control Module																																																										
A	2015	ATS	Chassis	Electronic Brake Control Module											V	V	V	V	V																																											
A	2015	ATS	Chassis	Parking Brake Control Module																																																										
A	2015	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	ATS	Chassis	Power Steering Control Module																																																										
A	2015	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	ATS	Chassis	Suspension Control Module																																													V															
A	2015	ATS	Body	Body Control Module Halogen									V																																																	
A	2015	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)									V																																																	
A	2015	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	ATS	Body	Passenger Presence Module																																																										
A	2015	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2015	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2015	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2015	ATS	Body	Radio/HVAC Control																																																										
A	2015	ATS	Body	Active Safety Control Module																																																										V	V	V	V	V	V	V	V	V	V

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
A	2015	ATS	Body	Headlamp Control Module																															V					V																						
A	2015	ATS	Body	Trailer Interface Control Module																																																									
A	2015	ATS	Body	Radio																		V	V																																					
A	2015	ATS	Body	Amplifier																				V	V																																			
A	2015	ATS	Body	Media Disc Player																																																								
A	2015	ATS	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																															
A	2015	ATS	Body	Navigation Control Module																																																								
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																								
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2015	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
A	2015	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																								
A	2015	ATS	Body	Seat Memory Control Module - Driver																																																								
A	2015	ATS	Body	Keyless Entry Control Module Coupe																																																								
A	2015	ATS	Body	Keyless Entry Control Module Sadan																																																								
A	2015	ATS	Body	Right Side Object Detection Control Module																																																								
A	2015	ATS	Body	Left Side Object Detection Control Module																																																								
A	2015	ATS	Body	Parking Assist Control Module																																							V	V	V															
A	2015	ATS	Body	Frontview Camera Module																										V	V																													
A	2015	ATS	Body	Steering Column Lock Control Module																																																								
A	2015	ATS	Body	Long Range Radar Sensor Module																																																								
A	2015	ATS	Body	Left Front Short Range Radar Sensor Module																																																								
A	2015	ATS	Body	Right Front Short Range Radar Sensor Module																																																								
A	2015	ATS	Body	Rear Short Range Radar Sensor Module																																																								
A	2015	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																								
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Engine Mount																																											V													
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																											V													
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																											V													
A	2015	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
A	2015	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																								
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																											V													
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Fuel Pump and Engine Mount																																											V													
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Active Grile Air Shutter And Engine Mount																																											V													
A	2015	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																							
A	2015	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																								
A	2015	CTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Engine Mount																																											V													
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																											V													
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																											V													
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																								
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																								
A	2015	CTS	Powertrain	Transfer Case Control Module																																												V													
A	2015	CTS	Chassis	Electronic Brake Control Module											V	V	V	V	V																																										
A	2015	CTS	Chassis	Parking Brake Control Module																																																								
A	2015	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2015	CTS	Chassis	Power Steering Control Module																																																								
A	2015	CTS	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2015	CTS	Chassis	Suspension Control Module																																													V												
A	2015	CTS	Body	Body Control Module Headlamp Type Halogen									V																									V	V																					
A	2015	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)									V																									V	V																					
A	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2015	CTS	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
A	2015	CTS	Body	Pedestrian Impact Detection Module																																																												
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Left																																																												
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Right																																																												
A	2015	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
A	2015	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
A	2015	CTS	Body	Active Safety Control Module																																																						V	V	V	V	V	V	V	V	V	V	V
A	2015	CTS	Body	Trailer Interface Control Module																																																												
A	2015	CTS	Body	Radio																		V	V																																								
A	2015	CTS	Body	Amplifier																				V	V																																						
A	2015	CTS	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																		
A	2015	CTS	Body	Navigation Control Module																																																											
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																											
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2015	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
A	2015	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
A	2015	CTS	Body	Seat Memory Control Module - Driver																																																											
A	2015	CTS	Body	Keyless Entry Control Module																																																											
A	2015	CTS	Body	Right Side Object Detection Control Module																																																											
A	2015	CTS	Body	Left Side Object Detection Control Module																																																											
A	2015	CTS	Body	Parking Assist Control Module																																																											
A	2015	CTS	Body	Frontview Camera Module																										V	V																																
A	2015	CTS	Body	Steering Column Lock Control Module																																																											
A	2015	CTS	Body	Long Range Radar Sensor Module																																																											
A	2015	CTS	Body	Left Front Short Range Radar Sensor Module																																																											
A	2015	CTS	Body	Right Front Short Range Radar Sensor Module																																																											
A	2015	CTS	Body	Rear Short Range Radar Sensor Module																																																											
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																													V																														
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																													V																														
A	2016	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
A	2016	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Automatic Transmission																																																											
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Manual Transmission																																																											
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Transmission Control Module																																																											
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																											
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																											
A	2016	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
A	2016	ATS	Powertrain	Transfer Case Control Module																																																											
A	2016	ATS	Powertrain	Rear Differential Clutch Control Module																																																											
A	2016	ATS	Chassis	Electronic Brake Control Module											V	V	V	V	V																																												
A	2016	ATS	Chassis	Parking Brake Control Module																																																											
A	2016	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2016	ATS	Chassis	Power Steering Control Module																																																											
A	2016	ATS	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2016	ATS	Chassis	Suspension Control Module																																																											
A	2016	ATS	Body	Body Control Module Halogen									V																																																	
A	2016	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)									V																																																	
A	2016	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2016	ATS	Body	Passenger Presence Module																																																											
A	2016	ATS	Body	Pedestrian Impact Detection Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2016	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2016	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2016	CTS	Body	Radio/HVAC Control																																																										
A	2016	CTS	Body	Vehicle Performance Data Recorder																																																										
A	2016	CTS	Body	Active Safety Control Module																																													V	V	V	V	V	V	V	V	V	V	V
A	2016	CTS	Body	Video Processing Control Module																																																										
A	2016	CTS	Body	Trailer Interface Control Module																																																										
A	2016	CTS	Body	Radio																		V	V																																							
A	2016	CTS	Body	Amplifier																				V	V																																					
A	2016	CTS	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																
A	2016	CTS	Body	Navigation Control Module																																																										
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2016	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2016	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2016	CTS	Body	Seat Memory Control Module - Passenger																																																										
A	2016	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2016	CTS	Body	Keyless Entry Control Module																																																										
A	2016	CTS	Body	Right Side Object Detection Control Module																																																										
A	2016	CTS	Body	Left Side Object Detection Control Module																																																										
A	2016	CTS	Body	Parking Assist Control Module																																																										
A	2016	CTS	Body	Frontview Camera Module																											V	V																														
A	2016	CTS	Body	Steering Column Lock Control Module																																																										
A	2016	CTS	Body	Long Range Radar Sensor Module																																																										
A	2016	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2016	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2016	CTS	Body	Rear Short Range Radar Sensor Module																																																										
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																										
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																										
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																										
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																										
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																										
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																										
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2004	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2004	(DM)CTS	Chassis	VES																																																										
D	2004	(DM)CTS	Body	Amplifier (Bose)																																																										
D	2004	(DM)CTS	Body	Amplifier (Delco)																																																										
D	2004	(DM)CTS	Body	Climate Control Panel																																																										
D	2004	(DM)CTS	Body	Dash Integration Module																																																										
D	2004	(DM)CTS	Body	Digital Radio Receiver																																																										
D	2004	(DM)CTS	Body	Driver Door Switch																																																										
D	2004	(DM)CTS	Body	Driver Door Module																																																										
D	2004	(DM)CTS	Body	Passenger Door Module																																																										
D	2004	(DM)CTS	Body	Left Rear Door Module																																																										
D	2004	(DM)CTS	Body	Right Rear Door Module																																																										
D	2004	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2004	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																										

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2016	CT6	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2016	CT6	Body	Passenger Presence Module																																																										
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Left																																																									
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Right																																																									
K	2016	CT6	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																									
K	2016	CT6	Body	Instrument Cluster Full Screen Display (UDV)																																																									
K	2016	CT6	Body	Radio Controls																																																									
K	2016	CT6	Body	HVAC Controls																																																									
K	2016	CT6	Body	Active Safety Control Module																																											V	V	V	V	V	V	V	V	V	V	V
K	2016	CT6	Body	Video Processing Control Module																																																									
K	2016	CT6	Body	Headlamp Control Module																															V					V																			
K	2016	CT6	Body	Trailer Interface Control Module																																																									
K	2016	CT6	Body	Radio																		V	V																																						
K	2016	CT6	Body	Amplifier																				V	V																																				
K	2016	CT6	Body	Infotainment Control Touchpad																																																									
K	2016	CT6	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																															
K	2016	CT6	Body	Navigation Control Module																																																									
K	2016	CT6	Body	Telematics Communication Interface Control Module																																																									
K	2016	CT6	Body	HVAC Control Module																																																									
K	2016	CT6	Body	Liftgate Control Module																																																									
K	2016	CT6	Body	Seat Memory Control Module - Passenger																																																									
K	2016	CT6	Body	Seat Memory Control Module - Left Rear																																																									
K	2016	CT6	Body	Seat Memory Control Module - Driver																																																									
K	2016	CT6	Body	Seat Memory Control Module - Right Rear																																																									
K	2016	CT6	Body	Keyless Entry Control Module																																																									
K	2016	CT6	Body	Left Side Object Detection Control Module																																																									
K	2016	CT6	Body	Parking Assist Control Module																																																									
K	2016	CT6	Body	Frontview Camera Module																											V	V																													
K	2016	CT6	Body	Long Range Radar Sensor Module																																																									
K	2016	CT6	Body	Left Front Short Range Radar Sensor Module																																																									
K	2016	CT6	Body	Right Front Short Range Radar Sensor Module																																																									
K	2016	CT6	Body	Rear Short Range Radar Sensor Module																																																									
K	2016	CT6	Body	Night Vision Camera Control Module																																																									
R	2014	ELR	Powertrain	Engine Control Module																																																									
R	2014	ELR	Powertrain	Trasmission Control Module																																																									
R	2014	ELR	Powertrain	Chassis Control Module																																																									
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module			V																																																					
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module 2				V		V																																																		
R	2014	ELR	Powertrain	Drive Motor Control Module 1																																																									
R	2014	ELR	Powertrain	Drive Motor Control Module 2																																																									
R	2014	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																									
R	2014	ELR	Chassis	Electronic Brake Control Module																																																									
R	2014	ELR	Chassis	Distance Sensing Cruise Control Module																V																																								
R	2014	ELR	Chassis	Parking Brake Control Module																																																									
R	2014	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																									
R	2014	ELR	Chassis	Power Steering Control Module																																																									
R	2014	ELR	Chassis	Steering Wheel Angle Sensor Module																																																									
R	2014	ELR	Chassis	Suspension Control Module																																																									
R	2014	ELR	Body	Body Control Module									V																																															
R	2014	ELR	Body	Pedestrian Impact Detection Module																																																									
R	2014	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
Y	2004	ALL	Body	Digital Radio Receiver																																																										
Y	2004	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2004	ALL	Body	Driver Door Module																																																										
Y	2004	ALL	Body	Driver Door Switch																																																										
Y	2004	ALL	Body	Driver Position Module																																																										
Y	2004	ALL	Body	Folding Top Module																																																										
Y	2004	ALL	Body	Head Up Display																																																										
Y	2004	ALL	Body	HVAC Control Module																																				V																					
Y	2004	ALL	Body	Instrument Panel Cluster																																																										
Y	2004	ALL	Body	Navigation Radio																																																										
Y	2004	ALL	Body	Passenger Door Module																																																										
Y	2004	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2004	ALL	Body	Steering Column Lock Module																																																										
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2005	ALL	Powertrain	Engine Control Module																																																										
Y	2005	ALL	Powertrain	Automatic Transmission																																																										
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2005	ALL	Chassis	Electronic Suspension Control																																																										
Y	2005	ALL	Chassis	Steering Wheel and Column																																																										
Y	2005	ALL	Body	Amplifier (Bose)																																																										
Y	2005	ALL	Body	Body Control Module																																																										
Y	2005	ALL	Body	CD Changer																																																										
Y	2005	ALL	Body	Digital Radio Receiver																																																										
Y	2005	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2005	ALL	Body	Driver Door Module																																																										
Y	2005	ALL	Body	Driver Door Switch																																																										
Y	2005	ALL	Body	Driver Position Module																																																										
Y	2005	ALL	Body	Folding Top Module																																																										
Y	2005	ALL	Body	Head Up Display																																																										
Y	2005	ALL	Body	HVAC Control Module																																				V																					
Y	2005	ALL	Body	Instrument Panel Cluster																																																										
Y	2005	ALL	Body	Navigation Radio																																																										
Y	2005	ALL	Body	Passenger Door Module																																																										
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2005	ALL	Body	Steering Column Lock Module																																																										
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2006	(YV)XLR	Powertrain	Engine Control Module																																																										
Y	2006	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																										
Y	2006	(YV)XLR	Powertrain	Automatic Transmission																																																										
Y	2006	(YV)XLR	Chassis	Electronic Brake Control Module																																																										
Y	2006	(YV)XLR	Chassis	Electronic Suspension Control																																																										
Y	2006	(YV)XLR	Chassis	Steering Wheel and Column																																																										
Y	2006	(YV)XLR	Body	Amplifier (Bose)																																																										
Y	2006	(YV)XLR	Body	Body Control Module																																																										
Y	2006	(YV)XLR	Body	CD Changer																																																										
Y	2006	(YV)XLR	Body	Digital Radio Receiver																																																										
Y	2006	(YV)XLR	Body	Distance Sensing Cruise Control																																																										
Y	2006	(YV)XLR	Body	Driver Door Module																																																										
Y	2006	(YV)XLR	Body	Driver Door Switch																																																										
Y	2006	(YV)XLR	Body	Driver Position Module																																																										
Y	2006	(YV)XLR	Body	Folding Top Module																																																										

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
Y	2007	(YV)XLR	Body	Navigation Radio																																																										
Y	2007	(YV)XLR	Body	Passenger Door Module																																																										
Y	2007	(YV)XLR	Body	Remote Control Door Lock Receiver																																																										
Y	2007	(YV)XLR	Body	Steering Column Lock Module																																																										
Y	2007	(YV)XLR	Body	Supplemental Inflatable Restraint																																																										
Y	2007	(YX)XLR-V	Powertrain	Engine Control Module																																																										
Y	2007	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	(YX)XLR-V	Powertrain	Transmission Control Module																																																										
Y	2007	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																										
Y	2007	(YX)XLR-V	Chassis	Electronic Suspension Control																																																										
Y	2007	(YX)XLR-V	Body	Amplifier (Bose)																																																										
Y	2007	(YX)XLR-V	Body	Body Control Module																																																										
Y	2007	(YX)XLR-V	Body	CD Changer																																																										
Y	2007	(YX)XLR-V	Body	Digital Radio Receiver																																																										
Y	2007	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																										
Y	2007	(YX)XLR-V	Body	Driver Door Module																																																										
Y	2007	(YX)XLR-V	Body	Driver Door Switch																																																										
Y	2007	(YX)XLR-V	Body	Driver Position Module																																																										
Y	2007	(YX)XLR-V	Body	Folding Top Module																																																										
Y	2007	(YX)XLR-V	Body	Headlamp Control Module																																																										
Y	2007	(YX)XLR-V	Body	Head Up Display																																																										
Y	2007	(YX)XLR-V	Body	HVAC Control Module																																				V																					
Y	2007	(YX)XLR-V	Body	Instrument Panel Cluster																																																										
Y	2007	(YX)XLR-V	Body	Navigation Radio																																																										
Y	2007	(YX)XLR-V	Body	Passenger Door Module																																																										
Y	2007	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																																										
Y	2007	(YX)XLR-V	Body	Steering Column Lock Module																																																										
Y	2007	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2008	ALL	Chassis	Electronic Suspension Control																																																										
Y	2008	ALL	Body	Amplifier (Bose)																																																										
Y	2008	ALL	Body	Body Control Module																																																										
Y	2008	ALL	Body	CD Changer																																																										
Y	2008	ALL	Body	Digital Radio Receiver																																																										
Y	2008	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2008	ALL	Body	Driver Door Module																																																										
Y	2008	ALL	Body	Driver Door Switch																																																										
Y	2008	ALL	Body	Driver Position Module																																																										
Y	2008	ALL	Body	Folding Top Module																																																										
Y	2008	ALL	Body	Headlamp Control Module																																																										
Y	2008	ALL	Body	Head Up Display																																																										
Y	2008	ALL	Body	HVAC Control Module																																				V																					
Y	2008	ALL	Body	Instrument Panel Cluster																																																										
Y	2008	ALL	Body	Navigation Radio																																																										
Y	2008	ALL	Body	Passenger Door Module																																																										
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																										

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
1	2013	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2013	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
1	2013	XTS	Body	Seat Memory Control Module																																																												
1	2013	XTS	Body	Keyless Entry Control Module																																																												
1	2013	XTS	Body	Right Side Object Detection Control Module																																																												
1	2013	XTS	Body	Left Side Object Detection Control Module																																																												
1	2013	XTS	Body	Parking Assist Control Module																																							V	V	V																	
1	2013	XTS	Body	Frontview Camera Module																											V	V																															
1	2013	XTS	Body	Long Range Radar Sensor Module																																																												
1	2013	XTS	Body	Left Front Short Range Radar Sensor Module																																																												
1	2013	XTS	Body	Right Front Short Range Radar Sensor Module																																																												
1	2013	XTS	Body	Rear Short Range Radar Sensor Module																																																												
1	2014	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																												
1	2014	XTS	Powertrain	(8) 3.6L LF3 Chassis Control Module																																																												
1	2014	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																												
1	2014	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
1	2014	XTS	Powertrain	(3) 3.6L LFX Chassis Control Module																																																												
1	2014	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
1	2014	XTS	Powertrain	Rear Differential Clutch Control Module																																																												
1	2014	XTS	Chassis	Electronic Brake Control Module											V	V	V	V	V																																													
1	2014	XTS	Chassis	Parking Brake Control Module																																																												
1	2014	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2014	XTS	Chassis	Power Steering Control Module																																																												
1	2014	XTS	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2014	XTS	Chassis	Suspension Control Module																																																												
1	2014	XTS	Body	Body Control Module									V								V																V	V																									
1	2014	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	XTS	Body	Passenger Presence Module																																																												
1	2014	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
1	2014	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
1	2014	XTS	Body	Radio/HVAC Control																																																												
1	2014	XTS	Body	Active Safety Control Module																																													V	V	V	V	V	V	V	V	V	V	V
1	2014	XTS	Body	Headlamp Control Module																															V					V																						
1	2014	XTS	Body	Radio																		V	V																																							
1	2014	XTS	Body	Amplifier																				V	V																																				
1	2014	XTS	Body	Media Disc Player																																																											
1	2014	XTS	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2014	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
1	2014	XTS	Body	Seat Memory Control Module - Passenger																																																											
1	2014	XTS	Body	Seat Memory Control Module - Driver																																																											
1	2014	XTS	Body	Keyless Entry Control Module																																																											
1	2014	XTS	Body	Right Side Object Detection Control Module																																																											
1	2014	XTS	Body	Left Side Object Detection Control Module																																																											
1	2014	XTS	Body	Parking Assist Control Module																																																											
1	2014	XTS	Body	Frontview Camera Module																											V	V																														
1	2014	XTS	Body	Long Range Radar Sensor Module																																																											
1	2014	XTS	Body	Left Front Short Range Radar Sensor Module																																																											
1	2014	XTS	Body	Right Front Short Range Radar Sensor Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
1	2016	XTS	Body	Body Control Module									V																								V	V																								
1	2016	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	XTS	Body	Passenger Presence Module																																																										
1	2016	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
1	2016	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
1	2016	XTS	Body	Radio/HVAC Control																																																										
1	2016	XTS	Body	Active Safety Control Module																																																										V	V	V	V	V	V	V	V	V	V	V
1	2016	XTS	Body	Video Processing Control Module																																																										
1	2016	XTS	Body	Radio																		V	V																																								
1	2016	XTS	Body	Amplifier																				V	V																																						
1	2016	XTS	Body	Media Disc Player																																																										
1	2016	XTS	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																
1	2016	XTS	Body	Telematics Communication Interface Control Module																																																										
1	2016	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2016	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
1	2016	XTS	Body	Seat Memory Control Module - Passenger																																																										
1	2016	XTS	Body	Seat Memory Control Module - Driver																																																										
1	2016	XTS	Body	Keyless Entry Control Module																																																										
1	2016	XTS	Body	Right Side Object Detection Control Module																																																										
1	2016	XTS	Body	Left Side Object Detection Control Module																																																										
1	2016	XTS	Body	Parking Assist Control Module																																																										
1	2016	XTS	Body	Frontview Camera Module																											V	V																															
1	2016	XTS	Body	Steering Column Lock Control Module																																																										
1	2016	XTS	Body	Long Range Radar Sensor Module																																																										
1	2016	XTS	Body	Left Front Short Range Radar Sensor Module																																																										
1	2016	XTS	Body	Right Front Short Range Radar Sensor Module																																																										
1	2016	XTS	Body	Rear Short Range Radar Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																									
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Engine Mount																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Engine Mount																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Engine Mount																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2013	ATS	Powertrain	Transfer Case Control Module																																																										
A	2013	ATS	Chassis	Electronic Brake Control Module																																																										
A	2013	ATS	Chassis	Parking Brake Control Module																																																										
A	2013	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	ATS	Chassis	Power Steering Control Module																																																										
A	2013	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	ATS	Chassis	Suspension Control Module																																																										
A	2013	ATS	Body	Body Control Module Halogen																																																										
A	2013	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2013	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	ATS	Body	Passenger Presence Module																																																										
A	2013	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2013	ATS	Body	Instrument Cluster																																																										
A	2013	ATS	Body	Radio/HVAC Control																																																										
A	2013	ATS	Body	Active Safety Control Module	V																																																									
A	2013	ATS	Body	Headlamp Control Module																																																										
A	2013	ATS	Body	Trailer Interface Control Module																																																										
A	2013	ATS	Body	Radio																																																										
A	2013	ATS	Body	Amplifier																																																										
A	2013	ATS	Body	Human Machine Interface Control Module																																																										
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2013	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2013	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2013	ATS	Body	Seat Memory Control Module																																																										
A	2013	ATS	Body	Keyless Entry Type Without Passive Entry																																																										
A	2013	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
A	2013	ATS	Body	Right Side Object Detection Control Module																																																										
A	2013	ATS	Body	Left Side Object Detection Control Module																																																										
A	2013	ATS	Body	Parking Assist Control Module																																																										
A	2013	ATS	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2013	ATS	Body	Steering Column Lock Control Module																																																								
A	2013	ATS	Body	Long Range Radar Sensor Module		V																																																							
A	2013	ATS	Body	Left Front Short Range Radar Sensor Module																																																									
A	2013	ATS	Body	Right Front Short Range Radar Sensor Module																																																									
A	2013	ATS	Body	Rear Short Range Radar Sensor Module																																																									
A	2014	ATS	Powertrain	(X) 2.0L LTG Engine Control Module																																																									
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																									
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																									
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																									
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																									
A	2014	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																									
A	2014	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																									
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																									
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																									
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																									
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																									
A	2014	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
A	2014	ATS	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																									
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																									
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																									
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																									
A	2014	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
A	2014	ATS	Powertrain	Transfer Case Control Module																																																									
A	2014	ATS	Chassis	Electronic Brake Control Module																																																									
A	2014	ATS	Chassis	Parking Brake Control Module																																																									
A	2014	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2014	ATS	Chassis	Power Steering Control Module																																																									
A	2014	ATS	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2014	ATS	Chassis	Suspension Control Module																																																									
A	2014	ATS	Body	Body Control Module Halogen			V																																																					
A	2014	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)			V																																																					
A	2014	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2014	ATS	Body	Passenger Presence Module																																																									
A	2014	ATS	Body	Pedestrian Impact Detection Module																																																									
A	2014	ATS	Body	Instrument Cluster																																																								
A	2014	ATS	Body	Radio/HVAC Control																																																								
A	2014	ATS	Body	Active Safety Control Module	V																																																							
A	2014	ATS	Body	Headlamp Control Module																																																								
A	2014	ATS	Body	Trailer Interface Control Module																																																								
A	2014	ATS	Body	Radio																																																								
A	2014	ATS	Body	Amplifier																																																								
A	2014	ATS	Body	Media Disc Player																																																								
A	2014	ATS	Body	Human Machine Interface Control Module																																																								
A	2014	ATS	Body	Navigation Control Module																																																								
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 9																																																								
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2014	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
A	2014	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																								
A	2014	ATS	Body	Seat Memory Control Module - Driver																																																								
A	2014	ATS	Body	Keyless Entry Type Without Passive Entry																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2014	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
A	2014	ATS	Body	Right Side Object Detection Control Module																																																										
A	2014	ATS	Body	Left Side Object Detection Control Module																																																										
A	2014	ATS	Body	Parking Assist Control Module																																																										
A	2014	ATS	Body	Frontview Camera Module																																																										
A	2014	ATS	Body	Steering Column Lock Control Module																																																										
A	2014	ATS	Body	Long Range Radar Sensor Module		V																																																								
A	2014	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2014	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2014	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Maunal Transmission																																																										
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2014	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2014	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
A	2014	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																										
A	2014	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
A	2014	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2014	CTS	Powertrain	Transfer Case Control Module																																																										
A	2014	CTS	Chassis	Electronic Brake Control Module																																																										
A	2014	CTS	Chassis	Parking Brake Control Module																																																										
A	2014	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	CTS	Chassis	Power Steering Control Module																																																										
A	2014	CTS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	CTS	Chassis	Suspension Control Module																																																										
A	2014	CTS	Body	Body Control Module Headlamp Type Halogen																																																										
A	2014	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	CTS	Body	Passenger Presence Module																																																										
A	2014	CTS	Body	Pedestrian Impact Detection Module																																																										
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Left				V	V																																																				
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Right				V	V																																																				
A	2014	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2014	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2014	CTS	Body	Radio/HVAC Control																																																										
A	2014	CTS	Body	Active Safety Control Module	V																																																									
A	2014	CTS	Body	Headlamp Control Module																																																										
A	2014	CTS	Body	Trailer Interface Control Module																																																										
A	2014	CTS	Body	Radio																																																										
A	2014	CTS	Body	Amplifier																																																										
A	2014	CTS	Body	Human Machine Interface Control Module																																																										
A	2014	CTS	Body	Navigation Control Module																																																										
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2014	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
A	2014	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2014	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2014	CTS	Body	Keyless Entry Control Module																																																										
A	2014	CTS	Body	Right Side Object Detection Control Module																																																										
A	2014	CTS	Body	Left Side Object Detection Control Module																																																										
A	2014	CTS	Body	Parking Assist Control Module																																																										
A	2014	CTS	Body	Frontview Camera Module																																																										
A	2014	CTS	Body	Steering Column Lock Control Module																																																										
A	2014	CTS	Body	Long Range Radar Sensor Module		V																																																								
A	2014	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2014	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2014	CTS	Body	Rear Short Range Radar Sensor Module																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2015	ATS	Powertrain	Transfer Case Control Module																																																										
A	2015	ATS	Chassis	Electronic Brake Control Module																																																										
A	2015	ATS	Chassis	Parking Brake Control Module																																																										
A	2015	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	ATS	Chassis	Power Steering Control Module																																																										
A	2015	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	ATS	Chassis	Suspension Control Module																																																										
A	2015	ATS	Body	Body Control Module Halogen																																																										
A	2015	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2015	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	ATS	Body	Passenger Presence Module																																																										
A	2015	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Left				V	V																																																				
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Right				V	V																																																				
A	2015	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2015	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2015	ATS	Body	Radio/HVAC Control																																																										
A	2015	ATS	Body	Active Safety Control Module	V																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2015	ATS	Body	Headlamp Control Module																																																								
A	2015	ATS	Body	Trailer Interface Control Module																																																								
A	2015	ATS	Body	Radio																																																								
A	2015	ATS	Body	Amplifier																																																								
A	2015	ATS	Body	Media Disc Player																																																								
A	2015	ATS	Body	Human Machine Interface Control Module																																																								
A	2015	ATS	Body	Navigation Control Module																																																								
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																								
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2015	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
A	2015	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																								
A	2015	ATS	Body	Seat Memory Control Module - Driver																																																								
A	2015	ATS	Body	Keyless Entry Control Module Coupe																																																								
A	2015	ATS	Body	Keyless Entry Control Module Sadan																																																								
A	2015	ATS	Body	Right Side Object Detection Control Module																																																								
A	2015	ATS	Body	Left Side Object Detection Control Module																																																								
A	2015	ATS	Body	Parking Assist Control Module																																																								
A	2015	ATS	Body	Frontview Camera Module																																																								
A	2015	ATS	Body	Steering Column Lock Control Module																																																								
A	2015	ATS	Body	Long Range Radar Sensor Module		V																																																							
A	2015	ATS	Body	Left Front Short Range Radar Sensor Module																																																								
A	2015	ATS	Body	Right Front Short Range Radar Sensor Module																																																								
A	2015	ATS	Body	Rear Short Range Radar Sensor Module																																																								
A	2015	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																								
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Engine Mount						V																																																		
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																								
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																								
A	2015	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
A	2015	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																								
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount						V																																																		
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Fuel Pump and Engine Mount																																																								
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Active Grile Air Shutter And Engine Mount																																																								
A	2015	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																								
A	2015	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																								
A	2015	CTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Engine Mount						V																																																		
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																								
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																								
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																								
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																								
A	2015	CTS	Powertrain	Transfer Case Control Module																																																								
A	2015	CTS	Chassis	Electronic Brake Control Module																																																								
A	2015	CTS	Chassis	Parking Brake Control Module																																																								
A	2015	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2015	CTS	Chassis	Power Steering Control Module																																																								
A	2015	CTS	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2015	CTS	Chassis	Suspension Control Module																																																								
A	2015	CTS	Body	Body Control Module Headlamp Type Halogen																																																								
A	2015	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
A	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2015	CTS	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2015	CTS	Body	Pedestrian Impact Detection Module																																																							
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Left				V	V																																																		
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Right				V	V																																																			
A	2015	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																							
A	2015	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																							
A	2015	CTS	Body	Active Safety Control Module	V																																																						
A	2015	CTS	Body	Trailer Interface Control Module																																																						
A	2015	CTS	Body	Radio																																																						
A	2015	CTS	Body	Amplifier																																																						
A	2015	CTS	Body	Human Machine Interface Control Module																																																						
A	2015	CTS	Body	Navigation Control Module																																																						
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																						
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																						
A	2015	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																						
A	2015	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																						
A	2015	CTS	Body	Seat Memory Control Module - Driver																																																						
A	2015	CTS	Body	Keyless Entry Control Module																																																						
A	2015	CTS	Body	Right Side Object Detection Control Module																																																						
A	2015	CTS	Body	Left Side Object Detection Control Module																																																						
A	2015	CTS	Body	Parking Assist Control Module																																																						
A	2015	CTS	Body	Frontview Camera Module																																																						
A	2015	CTS	Body	Steering Column Lock Control Module																																																						
A	2015	CTS	Body	Long Range Radar Sensor Module		V																																																				
A	2015	CTS	Body	Left Front Short Range Radar Sensor Module																																																						
A	2015	CTS	Body	Right Front Short Range Radar Sensor Module																																																						
A	2015	CTS	Body	Rear Short Range Radar Sensor Module																																																						
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																						
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																						
A	2016	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																						
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																						
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																						
A	2016	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																						
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Automatic Transmission							V																																															
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Manual Transmission																																																						
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Transmission Control Module																																																						
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																						
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																						
A	2016	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						
A	2016	ATS	Powertrain	Transfer Case Control Module																																																						
A	2016	ATS	Powertrain	Rear Differential Clutch Control Module																																																						
A	2016	ATS	Chassis	Electronic Brake Control Module																																																						
A	2016	ATS	Chassis	Parking Brake Control Module																																																						
A	2016	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																						
A	2016	ATS	Chassis	Power Steering Control Module																																																						
A	2016	ATS	Chassis	Steering Wheel Angle Sensor Module																																																						
A	2016	ATS	Chassis	Suspension Control Module																																																						
A	2016	ATS	Body	Body Control Module Halogen																																																						
A	2016	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																						
A	2016	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
A	2016	ATS	Body	Passenger Presence Module																																																						
A	2016	ATS	Body	Pedestrian Impact Detection Module																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Left				V	V																																																				
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Right				V	V																																																					
A	2016	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2016	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2016	ATS	Body	Radio/HVAC Control																																																										
A	2016	ATS	Body	Vehicle Performance Data Recorder																																																										
A	2016	ATS	Body	Trailer Interface Control Module																																																										
A	2016	ATS	Body	Radio																																																										
A	2016	ATS	Body	Amplifier																																																										
A	2016	ATS	Body	Rear Audio Control Module																																																										
A	2016	ATS	Body	Media Disc Player																																																										
A	2016	ATS	Body	Human Machine Interface Control Module																																																										
A	2016	ATS	Body	Navigation Control Module																																																										
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2016	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2016	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2016	ATS	Body	Seat Memory Control Module - Passenger																																																										
A	2016	ATS	Body	Seat Memory Control Module - Driver																																																										
A	2016	ATS	Body	Keyless Entry Control Module Coupe																																																										
A	2016	ATS	Body	Keyless Entry Control Module Sadan																																																										
A	2016	ATS	Body	Right Side Object Detection Control Module																																																										
A	2016	ATS	Body	Left Side Object Detection Control Module																																																										
A	2016	ATS	Body	Parking Assist Control Module																																																										
A	2016	ATS	Body	Frontview Camera Module																																																										
A	2016	ATS	Body	Steering Column Lock Control Module																																																										
A	2016	ATS	Body	Long Range Radar Sensor Module		V																																																								
A	2016	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2016	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2016	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2016	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
A	2016	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2016	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
A	2016	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
A	2016	CTS	Powertrain	(S) 3.6L LGX Engine Control Module																																																										
A	2016	CTS	Powertrain	(S) 3.6L LGX Transmission Control Module																																																										
A	2016	CTS	Powertrain	(6) 6.2L LT4 Engine Control Module																																																										
A	2016	CTS	Powertrain	(6) 6.2L LT4 Transmission Control Module																																																										
A	2016	CTS	Powertrain	Rear Differential Clutch Control Module																																																										
A	2016	CTS	Powertrain	Transfer Case Control Module																																																										
A	2016	CTS	Chassis	Electronic Brake Control Module																																																										
A	2016	CTS	Chassis	Parking Brake Control Module																																																										
A	2016	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2016	CTS	Chassis	Power Steering Control Module																																																										
A	2016	CTS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	CTS	Chassis	Suspension Control Module																																																										
A	2016	CTS	Body	Body Control Module Headlamp Type Halogen																																																										
A	2016	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2016	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	CTS	Body	Passenger Presence Module																																																										
A	2016	CTS	Body	Pedestrian Impact Detection Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Left				V	V																																																			
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Right				V	V																																																			
A	2016	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																								
A	2016	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																							
A	2016	CTS	Body	Radio/HVAC Control																																																							
A	2016	CTS	Body	Vehicle Performance Data Recorder																																																							
A	2016	CTS	Body	Active Safety Control Module	V																																																						
A	2016	CTS	Body	Video Processing Control Module								V	V	V	V	V																																												
A	2016	CTS	Body	Trailer Interface Control Module																																																							
A	2016	CTS	Body	Radio																																																							
A	2016	CTS	Body	Amplifier																																																						
A	2016	CTS	Body	Human Machine Interface Control Module																																																						
A	2016	CTS	Body	Navigation Control Module																																																						
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																						
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 10																																																						
A	2016	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																						
A	2016	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																						
A	2016	CTS	Body	Seat Memory Control Module - Passenger																																																						
A	2016	CTS	Body	Seat Memory Control Module - Driver																																																						
A	2016	CTS	Body	Keyless Entry Control Module																																																						
A	2016	CTS	Body	Right Side Object Detection Control Module																																																						
A	2016	CTS	Body	Left Side Object Detection Control Module																																																						
A	2016	CTS	Body	Parking Assist Control Module																																																						
A	2016	CTS	Body	Frontview Camera Module																																																						
A	2016	CTS	Body	Steering Column Lock Control Module																																																						
A	2016	CTS	Body	Long Range Radar Sensor Module		V																																																					
A	2016	CTS	Body	Left Front Short Range Radar Sensor Module																																																						
A	2016	CTS	Body	Right Front Short Range Radar Sensor Module																																																						
A	2016	CTS	Body	Rear Short Range Radar Sensor Module																																																						
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto													V	V	V																																							
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual													V	V	V																																							
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																V	V	V	V	V	V	V	V	V	V																													
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto													V	V	V																																							
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual													V	V	V																																							
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																V	V	V	V	V	V	V	V	V	V																													
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module													V	V													V	V	V	V	V																							
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																				
D	2004	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																		V	V	V																	
D	2004	(DM)CTS	Chassis	VES																																																						
D	2004	(DM)CTS	Body	Amplifier (Bose)																																					V	V	V																
D	2004	(DM)CTS	Body	Amplifier (Delco)																																					V	V	V																
D	2004	(DM)CTS	Body	Climate Control Panel																																								V	V	V	V	V											
D	2004	(DM)CTS	Body	Dash Integration Module																																					V	V	V						V	V	V							
D	2004	(DM)CTS	Body	Digital Radio Receiver																																																						
D	2004	(DM)CTS	Body	Driver Door Switch																																					V	V																
D	2004	(DM)CTS	Body	Driver Door Module																																					V	V	V							V		V	V					
D	2004	(DM)CTS	Body	Passenger Door Module																																					V	V	V							V		V	V					
D	2004	(DM)CTS	Body	Left Rear Door Module																																					V	V	V										V					
D	2004	(DM)CTS	Body	Right Rear Door Module																																					V	V	V										V					
D	2004	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																						
D	2004	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2004	(DM)CTS	Body	Instrument Panel Cluster																																					V	V																		
D	2004	(DM)CTS	Body	Memory Seat Module																																					V	V	V											V	V				
D	2004	(DM)CTS	Body	Personalization																																																			V	V		
D	2004	(DM)CTS	Body	Rear Integration Module																																					V	V	V																V	
D	2004	(DM)CTS	Body	Remote Function Actuation																																																							
D	2004	(DM)CTS	Body	Supplemental Inflatable Restraint																																					V																			V
D	2004	(DM)CTS	Body	TV Antenna Module																																					V	V	V																	
D	2004	(DM)CTS	Body	Vehicle Theft Deterrent																																					V																		
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto													V	V	V																																								
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual													V	V	V																																								
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																V	V	V	V	V	V	V	V	V	V	V																													
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto													V	V	V																																								
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual													V	V	V																																								
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																V	V	V	V	V	V	V	V	V	V	V																													
D	2004	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																		V	V	V																		
D	2004	(DR)CTS	Chassis	VES																																																							
D	2004	(DR)CTS	Body	Amplifier (Bose)																																					V	V	V																	
D	2004	(DR)CTS	Body	Amplifier (Delco)																																					V	V	V																	
D	2004	(DR)CTS	Body	Climate Control Panel																																								V	V	V	V	V												
D	2004	(DR)CTS	Body	Dash Integration Module																																					V	V	V						V	V	V								
D	2004	(DR)CTS	Body	Digital Radio Receiver																																																							
D	2004	(DR)CTS	Body	Driver Door Switch																																					V	V																		
D	2004	(DR)CTS	Body	Driver Door Module																																					V	V	V							V		V								
D	2004	(DR)CTS	Body	Passenger Door Module																																					V	V	V							V		V								
D	2004	(DR)CTS	Body	Left Rear Door Module																																					V	V	V																	
D	2004	(DR)CTS	Body	Right Rear Door Module																																					V	V	V																	
D	2004	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																							
D	2004	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																							
D	2004	(DR)CTS	Body	Instrument Panel Cluster																																					V	V																		
D	2004	(DR)CTS	Body	Memory Seat Module																																					V	V	V											V	V				
D	2004	(DR)CTS	Body	Personalization																																																		V	V		
D	2004	(DR)CTS	Body	Rear Integration Module																																					V	V	V																V	
D	2004	(DR)CTS	Body	Remote Function Actuation																																																							
D	2004	(DR)CTS	Body	Supplemental Inflatable Restraint																																					V																			V
D	2004	(DR)CTS	Body	TV Antenna Module																																					V	V	V																	
D	2004	(DR)CTS	Body	Vehicle Theft Deterrent																																					V																		
D	2004	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module													V	V	V																																								
D	2004	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																		V	V	V																		
D	2004	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																							
D	2004	(DN)CTS-V	Chassis	VES																																																							
D	2004	(DN)CTS-V	Body	Amplifier (Bose)																																					V	V	V																	
D	2004	(DN)CTS-V	Body	Amplifier (Delco)																																					V	V	V																	
D	2004	(DN)CTS-V	Body	Climate Control Panel																																								V	V	V	V	V												
D	2004	(DN)CTS-V	Body	Dash Integration Module																																					V	V	V						V	V	V								
D	2004	(DN)CTS-V	Body	Digital Radio Receiver																																																							
D	2004	(DN)CTS-V	Body	Driver Door Switch																																					V	V																		
D	2004	(DN)CTS-V	Body	Driver Door Module																																					V	V	V							V		V								
D	2004	(DN)CTS-V	Body	Passenger Door Module																																					V	V	V							V		V								
D	2004	(DN)CTS-V	Body	Left Rear Door Module																																					V	V	V																	
D	2004	(DN)CTS-V	Body	Right Rear Door Module																																					V	V	V																	
D	2004	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2004	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																									
D	2004	(DN)CTS-V	Body	Instrument Panel Cluster																																						V	V																		
D	2004	(DN)CTS-V	Body	Memory Seat Module																																						V	V	V											V	V					
D	2004	(DN)CTS-V	Body	Personalization																																																					V	V			
D	2004	(DN)CTS-V	Body	Rear Integration Module																																						V	V	V																V	
D	2004	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																									
D	2004	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																						V																			V
D	2004	(DN)CTS-V	Body	TV Antenna Module																																						V	V	V																	
D	2004	(DN)CTS-V	Body	Vehicle Theft Deterrent																																						V																			
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module													V	V													V	V	V	V	V																										
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																							
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module													V	V													V	V	V	V	V																										
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																							
D	2005	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																		V	V	V																					
D	2005	(DM)CTS	Chassis	VES																																																									
D	2005	(DM)CTS	Body	Amplifier (Bose)																																						V	V	V																	
D	2005	(DM)CTS	Body	Amplifier (Delco)																																						V	V	V																	
D	2005	(DM)CTS	Body	Climate Control Panel																																									V	V	V	V	V												
D	2005	(DM)CTS	Body	Dash Integration Module																																						V	V	V							V	V	V								
D	2005	(DM)CTS	Body	Digital Radio Receiver																																																									
D	2005	(DM)CTS	Body	Driver Door Switch																																						V	V																		
D	2005	(DM)CTS	Body	Driver Door Module																																						V	V	V						V		V									
D	2005	(DM)CTS	Body	Passenger Door Module																																						V	V	V						V		V								
D	2005	(DM)CTS	Body	Left Rear Door Module																																						V	V	V																	
D	2005	(DM)CTS	Body	Right Rear Door Module																																						V	V	V																	
D	2005	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																									
D	2005	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																									
D	2005	(DM)CTS	Body	Instrument Panel Cluster																																						V	V																		
D	2005	(DM)CTS	Body	Memory Seat Module																																						V	V	V										V	V					
D	2005	(DM)CTS	Body	Personalization																																																				V	V			
D	2005	(DM)CTS	Body	Rear Integration Module																																						V	V	V															V	
D	2005	(DM)CTS	Body	Remote Control Door Lock Receiver																																																									
D	2005	(DM)CTS	Body	Supplemental Inflatable Restraint																																						V																			V
D	2005	(DM)CTS	Body	TV Antenna Module																																						V	V	V																	
D	2005	(DM)CTS	Body	Vehicle Theft Deterrent																																						V																			
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module													V	V													V	V	V	V	V																										
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																							
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module													V	V													V	V	V	V	V																										
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																							
D	2005	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																		V	V	V																					
D	2005	(DP)CTS	Chassis	VES																																																									
D	2005	(DP)CTS	Body	Amplifier (Bose)																																						V	V	V																	
D	2005	(DP)CTS	Body	Amplifier (Delco)																																						V	V	V																	
D	2005	(DP)CTS	Body	Climate Control Panel																																									V	V	V	V	V												
D	2005	(DP)CTS	Body	Dash Integration Module																																						V	V	V						V	V	V								
D	2005	(DP)CTS	Body	Digital Radio Receiver																																																									
D	2005	(DP)CTS	Body	Driver Door Switch																																						V	V																		
D	2005	(DP)CTS	Body	Driver Door Module																																						V	V	V						V		V	V								
D	2005	(DP)CTS	Body	Passenger Door Module																																						V	V	V						V		V	V								
D	2005	(DP)CTS	Body	Left Rear Door Module																																						V	V	V									V							
D	2005	(DP)CTS	Body	Right Rear Door Module																																						V	V	V									V							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2005	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2005	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2005	(DP)CTS	Body	Instrument Panel Cluster																																					V	V																			
D	2005	(DP)CTS	Body	Memory Seat Module																																					V	V	V												V	V				
D	2005	(DP)CTS	Body	Personalization																																																				V	V		
D	2005	(DP)CTS	Body	Rear Integration Module																																					V	V	V																	V	
D	2005	(DP)CTS	Body	Remote Control Door Lock Receiver																																																								
D	2005	(DP)CTS	Body	Supplemental Inflatable Restraint																																					V																				V
D	2005	(DP)CTS	Body	TV Antenna Module																																					V	V	V																		
D	2005	(DP)CTS	Body	Vehicle Theft Deterrent																																					V																		
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module													V	V													V	V	V	V	V																									
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module															V	V	V	V		V	V	V	V									V	V	V																						
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module													V	V													V	V	V	V	V																									
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module															V	V	V	V		V	V	V	V									V	V	V																						
D	2005	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																		V	V	V																		
D	2005	(DR)CTS	Chassis	VES																																																								
D	2005	(DR)CTS	Body	Amplifier (Bose)																																					V	V	V																		
D	2005	(DR)CTS	Body	Amplifier (Delco)																																					V	V	V																		
D	2005	(DR)CTS	Body	Climate Control Panel																																								V	V	V	V	V												
D	2005	(DR)CTS	Body	Dash Integration Module																																					V	V	V						V	V	V									
D	2005	(DR)CTS	Body	Digital Radio Receiver																																																								
D	2005	(DR)CTS	Body	Driver Door Switch																																					V	V																			
D	2005	(DR)CTS	Body	Driver Door Module																																					V	V	V							V		V									
D	2005	(DR)CTS	Body	Passenger Door Module																																					V	V	V							V		V									
D	2005	(DR)CTS	Body	Left Rear Door Module																																					V	V	V																		
D	2005	(DR)CTS	Body	Right Rear Door Module																																					V	V	V																		
D	2005	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																									
D	2005	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																									
D	2005	(DR)CTS	Body	Instrument Panel Cluster																																					V	V																			
D	2005	(DR)CTS	Body	Memory Seat Module																																					V	V	V													V	V				
D	2005	(DR)CTS	Body	Personalization																																																				V	V		
D	2005	(DR)CTS	Body	Radio																																													V										V
D	2005	(DR)CTS	Body	Rear Integration Module																																					V	V	V																	V	
D	2005	(DR)CTS	Body	Remote Control Door Lock Receiver																																																								
D	2005	(DR)CTS	Body	Supplemental Inflatable Restraint																																					V																				V
D	2005	(DR)CTS	Body	TV Antenna Module																																					V	V	V																		
D	2005	(DR)CTS	Body	Vehicle Theft Deterrent																																					V																		
D	2005	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module													V	V	V																																									
D	2005	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																		V	V	V																		
D	2005	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																								
D	2005	(DN)CTS-V	Chassis	VES																																																								
D	2005	(DN)CTS-V	Body	Amplifier (Bose)																																					V	V	V																		
D	2005	(DN)CTS-V	Body	Amplifier (Delco)																																					V	V	V																		
D	2005	(DN)CTS-V	Body	Climate Control Panel																																								V	V	V	V	V												
D	2005	(DN)CTS-V	Body	Dash Integration Module																																					V	V	V						V	V	V									
D	2005	(DN)CTS-V	Body	Digital Radio Receiver																																																								
D	2005	(DN)CTS-V	Body	Driver Door Switch																																					V	V																			
D	2005	(DN)CTS-V	Body	Driver Door Module																																					V	V	V							V		V									
D	2005	(DN)CTS-V	Body	Passenger Door Module																																					V	V	V							V		V									
D	2005	(DN)CTS-V	Body	Left Rear Door Module																																					V	V	V																		
D	2005	(DN)CTS-V	Body	Right Rear Door Module																																					V	V	V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2005	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																								
D	2005	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																								
D	2005	(DN)CTS-V	Body	Instrument Panel Cluster																																					V	V																		
D	2005	(DN)CTS-V	Body	Memory Seat Module																																					V	V	V											V	V					
D	2005	(DN)CTS-V	Body	Personalization																																																					V	V		
D	2005	(DN)CTS-V	Body	Radio																																															V									V
D	2005	(DN)CTS-V	Body	Rear Integration Module																																					V	V	V																V	
D	2005	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																								
D	2005	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																					V																			V
D	2005	(DN)CTS-V	Body	TV Antenna Module																																					V	V	V																	
D	2005	(DN)CTS-V	Body	Vehicle Theft Deterrent																																					V																			
D	2005	(DC)STS-V8	Powertrain	Engine Control Module													V														V		V		V																									
D	2005	(DC)STS-V8	Powertrain	Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																						
D	2005	(DC)STS-V8	Chassis	Electronic Brake Control Module																																			V																					
D	2005	(DC)STS-V8	Chassis	Electronic Suspension Control																																																								
D	2005	(DC)STS-V8	Body	Amplifier (Bose)																																																								
D	2005	(DC)STS-V8	Body	Digital Radio Receiver																																																								
D	2005	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																								
D	2005	(DC)STS-V8	Body	Driver Door Module																																					V																			
D	2005	(DC)STS-V8	Body	Driver Door Switch																																																								
D	2005	(DC)STS-V8	Body	Driver Position Module																																						V	V																	
D	2005	(DC)STS-V8	Body	Headlamp Control Module																																																								
D	2005	(DC)STS-V8	Body	Head Up Display																																																								
D	2005	(DC)STS-V8	Body	HVAC Control Module																																								V	V	V	V	V												
D	2005	(DC)STS-V8	Body	Instrument Panel Cluster																																																								
D	2005	(DC)STS-V8	Body	Instrument Panel Module																																						V	V																	
D	2005	(DC)STS-V8	Body	Left Rear Door Module																																					V																			
D	2005	(DC)STS-V8	Body	Passenger Door Module																																					V																			
D	2005	(DC)STS-V8	Body	Uplevel Radio																																																								
D	2005	(DC)STS-V8	Body	Navigation Radio																																																								
D	2005	(DC)STS-V8	Body	Rear Integration Module																																					V	V	V			V														
D	2005	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																					V																			
D	2005	(DC)STS-V8	Body	Right Rear Door Module																																					V																			
D	2005	(DC)STS-V8	Body	Steering Column Lock Module																																																								
D	2005	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																					V																			V
D	2005	(DC)STS-V8	Body	TV Antenna Module																																					V	V	V																	
D	2005	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																								
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module													V	V													V		V		V																									
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																						
D	2005	(DW)STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																						
D	2005	(DW)STS	Chassis	Electronic Brake Control Module																																			V																					
D	2005	(DW)STS	Chassis	Electronic Suspension Control																																																								
D	2005	(DW)STS	Body	Amplifier (Bose)																																																								
D	2005	(DW)STS	Body	Digital Radio Receiver																																																								
D	2005	(DW)STS	Body	Distance Sensing Cruise Control																																																								
D	2005	(DW)STS	Body	Driver Door Module																																					V																			
D	2005	(DW)STS	Body	Driver Door Switch																																																								
D	2005	(DW)STS	Body	Driver Position Module																																						V	V																	
D	2005	(DW)STS	Body	Headlamp Control Module																																																								
D	2005	(DW)STS	Body	Head Up Display																																																								
D	2005	(DW)STS	Body	HVAC Control Module																																								V	V	V	V	V												

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2005	(DW)STS	Body	Instrument Panel Cluster																																																										
D	2005	(DW)STS	Body	Instrument Panel Module																																						V	V																		
D	2005	(DW)STS	Body	Left Rear Door Module																																				V																				
D	2005	(DW)STS	Body	Passenger Door Module																																				V																				
D	2005	(DW)STS	Body	Uplevel Radio																																																								
D	2005	(DW)STS	Body	Navigation Radio																																																								
D	2005	(DW)STS	Body	Rear Integration Module																																				V	V	V			V														
D	2005	(DW)STS	Body	Remote Control Door Lock Receiver																																				V																			
D	2005	(DW)STS	Body	Right Rear Door Module																																				V																			
D	2005	(DW)STS	Body	Steering Column Lock Module																																																							
D	2005	(DW)STS	Body	Supplemental Inflatable Restraint																																				V																			V
D	2005	(DW)STS	Body	TV Antenna Module																																				V	V	V																	
D	2005	(DW)STS	Body	Vehicle Comm. Interface Module																																																							
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																										V	V	V	V	V																									
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module															V	V	V	V		V	V	V	V								V	V	V																						
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																										V	V	V	V	V																									
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module															V	V	V	V		V	V	V	V								V	V	V																						
D	2006	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																	V	V	V																			
D	2006	(DM)CTS	Chassis	Tire Pressure Monitor																																																						
D	2006	(DM)CTS	Chassis	VES																																																						
D	2006	(DM)CTS	Body	Amplifier (Bose)																																				V	V	V																	
D	2006	(DM)CTS	Body	Amplifier (Delco)																																				V	V	V																	
D	2006	(DM)CTS	Body	Climate Control Panel																																							V	V	V	V	V												
D	2006	(DM)CTS	Body	Dash Integration Module																																				V	V	V						V	V	V								
D	2006	(DM)CTS	Body	Digital Radio Receiver																																																						
D	2006	(DM)CTS	Body	Driver Door Switch																																				V	V																	
D	2006	(DM)CTS	Body	Driver Door Module																																				V	V	V							V		V	V						
D	2006	(DM)CTS	Body	Passenger Door Module																																				V	V	V							V		V	V						
D	2006	(DM)CTS	Body	Left Rear Door Module																																				V	V	V										V						
D	2006	(DM)CTS	Body	Right Rear Door Module																																				V	V	V										V						
D	2006	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																						
D	2006	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																						
D	2006	(DM)CTS	Body	Instrument Panel Cluster																																				V	V																	
D	2006	(DM)CTS	Body	Memory Seat Module																																				V	V	V												V	V			
D	2006	(DM)CTS	Body	Personalization																																																		V	V		
D	2006	(DM)CTS	Body	Radio																																												V									V
D	2006	(DM)CTS	Body	Rear Integration Module																																				V	V	V							V								V	
D	2006	(DM)CTS	Body	Remote Control Door Lock Receiver																																																						
D	2006	(DM)CTS	Body	Supplemental Inflatable Restraint																																				V																			V
D	2006	(DM)CTS	Body	TV Antenna Module																																				V	V	V																	
D	2006	(DM)CTS	Body	Vehicle Theft Deterrent																																				V																			
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																										V	V	V	V	V																									
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module															V	V	V	V		V	V	V	V								V	V	V																						
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																										V	V	V	V	V																									
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module															V	V	V	V		V	V	V	V								V	V	V																						
D	2006	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																	V	V	V																			
D	2006	(DP)CTS	Chassis	Tire Pressure Monitor																																																						
D	2006	(DP)CTS	Chassis	VES																																																						
D	2006	(DP)CTS	Body	Amplifier (Bose)																																				V	V	V																	
D	2006	(DP)CTS	Body	Amplifier (Delco)																																				V	V	V																	
D	2006	(DP)CTS	Body	Climate Control Panel																																							V	V	V	V	V												

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2006	(DP)CTS	Body	Dash Integration Module																																					V	V	V						V	V	V								
D	2006	(DP)CTS	Body	Digital Radio Receiver																																																							
D	2006	(DP)CTS	Body	Driver Door Switch																																					V	V																		
D	2006	(DP)CTS	Body	Driver Door Module																																					V	V	V							V		V								
D	2006	(DP)CTS	Body	Passenger Door Module																																					V	V	V							V		V								
D	2006	(DP)CTS	Body	Left Rear Door Module																																					V	V	V																	
D	2006	(DP)CTS	Body	Right Rear Door Module																																					V	V	V																	
D	2006	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																							
D	2006	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																							
D	2006	(DP)CTS	Body	Instrument Panel Cluster																																					V	V																		
D	2006	(DP)CTS	Body	Memory Seat Module																																					V	V	V													V	V			
D	2006	(DP)CTS	Body	Personalization																																																			V	V		
D	2006	(DP)CTS	Body	Radio																																													V									V
D	2006	(DP)CTS	Body	Rear Integration Module																																					V	V	V							V									V	
D	2006	(DP)CTS	Body	Remote Control Door Lock Receiver																																																							
D	2006	(DP)CTS	Body	Supplemental Inflatable Restraint																																					V																			V
D	2006	(DP)CTS	Body	TV Antenna Module																																					V	V	V																	
D	2006	(DP)CTS	Body	Vehicle Theft Deterrent																																					V																		
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																											V	V	V	V	V																									
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																						
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V	V	V	V	V																									
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																						
D	2006	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																			V	V	V																	
D	2006	(DR)CTS	Chassis	Tire Pressure Monitor																																																							
D	2006	(DR)CTS	Chassis	VES																																																							
D	2006	(DR)CTS	Body	Amplifier (Bose)																																					V	V	V																	
D	2006	(DR)CTS	Body	Amplifier (Delco)																																					V	V	V																	
D	2006	(DR)CTS	Body	Climate Control Panel																																								V	V	V	V	V											
D	2006	(DR)CTS	Body	Dash Integration Module																																					V	V	V						V	V	V								
D	2006	(DR)CTS	Body	Digital Radio Receiver																																																							
D	2006	(DR)CTS	Body	Driver Door Switch																																					V	V																		
D	2006	(DR)CTS	Body	Driver Door Module																																					V	V	V							V		V								
D	2006	(DR)CTS	Body	Passenger Door Module																																					V	V	V							V		V								
D	2006	(DR)CTS	Body	Left Rear Door Module																																					V	V	V																	
D	2006	(DR)CTS	Body	Right Rear Door Module																																					V	V	V																	
D	2006	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																							
D	2006	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																							
D	2006	(DR)CTS	Body	Instrument Panel Cluster																																					V	V																		
D	2006	(DR)CTS	Body	Memory Seat Module																																					V	V	V													V	V			
D	2006	(DR)CTS	Body	Personalization																																																			V	V		
D	2006	(DR)CTS	Body	Radio																																													V									V
D	2006	(DR)CTS	Body	Rear Integration Module																																					V	V	V							V									V	
D	2006	(DR)CTS	Body	Remote Control Door Lock Receiver																																																							
D	2006	(DR)CTS	Body	Supplemental Inflatable Restraint																																					V																			V
D	2006	(DR)CTS	Body	TV Antenna Module																																					V	V	V																	
D	2006	(DR)CTS	Body	Vehicle Theft Deterrent																																					V																		
D	2006	(DN)CTS-V	Powertrain	Engine Control Module																											V		V	V																										
D	2006	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																			V	V	V																	
D	2006	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																							
D	2006	(DN)CTS-V	Chassis	VES																																																							
D	2006	(DN)CTS-V	Body	Amplifier (Bose)																																					V	V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2006	(DN)CTS-V	Body	Amplifier (Delco)																																						V	V	V																
D	2006	(DN)CTS-V	Body	Climate Control Panel																																									V	V	V	V	V										
D	2006	(DN)CTS-V	Body	Dash Integration Module																																					V	V	V						V	V	V								
D	2006	(DN)CTS-V	Body	Digital Radio Receiver																																																							
D	2006	(DN)CTS-V	Body	Driver Door Switch																																					V	V																		
D	2006	(DN)CTS-V	Body	Driver Door Module																																					V	V	V							V		V								
D	2006	(DN)CTS-V	Body	Passenger Door Module																																					V	V	V							V		V								
D	2006	(DN)CTS-V	Body	Left Rear Door Module																																					V	V	V																
D	2006	(DN)CTS-V	Body	Right Rear Door Module																																					V	V	V																
D	2006	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																							
D	2006	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																						
D	2006	(DN)CTS-V	Body	Instrument Panel Cluster																																					V	V																	
D	2006	(DN)CTS-V	Body	Memory Seat Module																																					V	V	V												V	V			
D	2006	(DN)CTS-V	Body	Personalization																																																			V	V		
D	2006	(DN)CTS-V	Body	Rear Integration Module																																					V	V	V							V								V	
D	2006	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																						
D	2006	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																					V																		V
D	2006	(DN)CTS-V	Body	TV Antenna Module																																					V	V	V																
D	2006	(DN)CTS-V	Body	Vehicle Theft Deterrent																																					V																		
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Engine Controls													V														V		V		V																								
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																				
D	2006	(DC)STS-V8	Chassis	Electronic Brake Control Module																																			V																		
D	2006	(DC)STS-V8	Chassis	Electronic Suspension Control																																																						
D	2006	(DC)STS-V8	Body	Amplifier (Bose)																																																						
D	2006	(DC)STS-V8	Body	Digital Radio Receiver																																																						
D	2006	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																						
D	2006	(DC)STS-V8	Body	Driver Door Module																																					V																		
D	2006	(DC)STS-V8	Body	Driver Door Switch																																																						
D	2006	(DC)STS-V8	Body	Driver Position Module																																							V	V															
D	2006	(DC)STS-V8	Body	Headlamp Control Module																																																						
D	2006	(DC)STS-V8	Body	Head Up Display																																																						
D	2006	(DC)STS-V8	Body	HVAC Control Module																																								V	V	V	V	V											
D	2006	(DC)STS-V8	Body	Instrument Panel Cluster																																																						
D	2006	(DC)STS-V8	Body	Instrument Panel Module																																							V	V															
D	2006	(DC)STS-V8	Body	Left Rear Door Module																																					V																		
D	2006	(DC)STS-V8	Body	Passenger Door Module																																					V																		
D	2006	(DC)STS-V8	Body	Uplevel Radio																																																						
D	2006	(DC)STS-V8	Body	Navigation Radio																																																						
D	2006	(DC)STS-V8	Body	Rear Integration Module																																					V	V	V			V													
D	2006	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																					V																		
D	2006	(DC)STS-V8	Body	Right Rear Door Module																																					V																		
D	2006	(DC)STS-V8	Body	Steering Column Lock Module																																																						
D	2006	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																					V																		V
D	2006	(DC)STS-V8	Body	TV Antenna Module																																					V	V	V																
D	2006	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																						
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V		V																								
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																				
D	2006	(DW)STS	Chassis	Electronic Brake Control Module																																			V																		
D	2006	(DW)STS	Chassis	Electronic Suspension Control																																																						
D	2006	(DW)STS	Body	Amplifier (Bose)																																																						
D	2006	(DW)STS	Body	Digital Radio Receiver																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2006	(DW)STS	Body	Distance Sensing Cruise Control																																																							
D	2006	(DW)STS	Body	Driver Door Module																																					V																		
D	2006	(DW)STS	Body	Driver Door Switch																																																							
D	2006	(DW)STS	Body	Driver Position Module																																						V	V																
D	2006	(DW)STS	Body	Headlamp Control Module																																																							
D	2006	(DW)STS	Body	Head Up Display																																																							
D	2006	(DW)STS	Body	HVAC Control Module																																								V	V	V	V	V												
D	2006	(DW)STS	Body	Instrument Panel Cluster																																																							
D	2006	(DW)STS	Body	Instrument Panel Module																																						V	V																
D	2006	(DW)STS	Body	Left Rear Door Module																																					V																		
D	2006	(DW)STS	Body	Passenger Door Module																																					V																		
D	2006	(DW)STS	Body	Uplevel Radio																																																							
D	2006	(DW)STS	Body	Navigation Radio																																																							
D	2006	(DW)STS	Body	Rear Integration Module																																					V	V	V			V													
D	2006	(DW)STS	Body	Remote Control Door Lock Receiver																																					V																		
D	2006	(DW)STS	Body	Right Rear Door Module																																					V																		
D	2006	(DW)STS	Body	Steering Column Lock Module																																																							
D	2006	(DW)STS	Body	Supplemental Inflatable Restraint																																					V																		V
D	2006	(DW)STS	Body	TV Antenna Module																																					V	V	V																
D	2006	(DW)STS	Body	Vehicle Comm. Interface Module																																																							
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Engine Control Module																											V		V																										
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																							
D	2006	(DX)STS-V	Chassis	Electronic Brake Control Module																																			V																				
D	2006	(DX)STS-V	Chassis	Electronic Suspension Control																																																							
D	2006	(DX)STS-V	Body	Amplifier (Bose)																																																							
D	2006	(DX)STS-V	Body	Digital Radio Receiver																																																							
D	2006	(DX)STS-V	Body	Distance Sensing Cruise Control																																																							
D	2006	(DX)STS-V	Body	Driver Door Module																																					V																		
D	2006	(DX)STS-V	Body	Driver Door Switch																																																							
D	2006	(DX)STS-V	Body	Driver Position Module																																						V	V																
D	2006	(DX)STS-V	Body	Headlamp Control Module																																																							
D	2006	(DX)STS-V	Body	Head Up Display																																																							
D	2006	(DX)STS-V	Body	HVAC Control Module																																								V	V	V	V	V												
D	2006	(DX)STS-V	Body	Instrument Panel Cluster																																																							
D	2006	(DX)STS-V	Body	Instrument Panel Module																																						V	V																
D	2006	(DX)STS-V	Body	Left Rear Door Module																																					V																		
D	2006	(DX)STS-V	Body	Passenger Door Module																																					V																		
D	2006	(DX)STS-V	Body	Uplevel Radio																																																							
D	2006	(DX)STS-V	Body	Navigation Radio																																																							
D	2006	(DX)STS-V	Body	Rear Integration Module																																					V	V	V			V													
D	2006	(DX)STS-V	Body	Remote Control Door Lock Receiver																																					V																		
D	2006	(DX)STS-V	Body	Right Rear Door Module																																					V																		
D	2006	(DX)STS-V	Body	Steering Column Lock Module																																																							
D	2006	(DX)STS-V	Body	Supplemental Inflatable Restraint																																					V																		V
D	2006	(DX)STS-V	Body	TV Antenna Module																																					V	V	V																
D	2006	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																							
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																											V	V	V	V																									
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																											V	V	V	V																									
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module															V	V	V	V		V	V	V	V									V	V	V																					
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																											V	V	V	V																									
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																											V	V	V	V																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V									V	V	V																						
D	2007	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																			V	V	V																			
D	2007	(DM)CTS	Chassis	VES																																																								
D	2007	(DM)CTS	Body	Amplifier (Bose)																																					V	V	V																		
D	2007	(DM)CTS	Body	Amplifier (Delco)																																					V	V	V																		
D	2007	(DM)CTS	Body	Climate Control Panel																																								V	V	V	V	V												
D	2007	(DM)CTS	Body	Dash Integration Module																																					V	V	V						V	V	V									
D	2007	(DM)CTS	Body	Digital Radio Receiver																																																							
D	2007	(DM)CTS	Body	Driver Door Switch																																					V	V																		
D	2007	(DM)CTS	Body	Driver Door Module																																					V	V	V							V		V	V							
D	2007	(DM)CTS	Body	Passenger Door Module																																					V	V	V							V		V	V							
D	2007	(DM)CTS	Body	Left Rear Door Module																																					V	V	V										V							
D	2007	(DM)CTS	Body	Right Rear Door Module																																					V	V	V										V							
D	2007	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																							
D	2007	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																							
D	2007	(DM)CTS	Body	Instrument Panel Cluster																																					V	V																		
D	2007	(DM)CTS	Body	Memory Seat Module																																					V	V	V												V	V				
D	2007	(DM)CTS	Body	Personalization																																																			V	V		
D	2007	(DM)CTS	Body	Rear Integration Module																																					V	V	V							V									V	
D	2007	(DM)CTS	Body	Remote Control Door Lock Receiver																																																						
D	2007	(DM)CTS	Body	Supplemental Inflatable Restraint																																					V																			V
D	2007	(DM)CTS	Body	Theft Deterrent Module																																					V																		
D	2007	(DM)CTS	Body	TV Antenna Module																																					V	V	V																		
D	2007	(DM)CTS	Body	Vehicle Comm. Interface Module																																																						
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																										V	V	V	V																											
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																										V	V	V	V																											
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																V	V	V	V		V	V	V	V									V	V	V																						
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																										V	V	V	V																											
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																										V	V	V	V																											
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V									V	V	V																						
D	2007	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																			V	V	V																		
D	2007	(DP)CTS	Chassis	VES																																																							
D	2007	(DP)CTS	Body	Amplifier (Bose)																																					V	V	V																		
D	2007	(DP)CTS	Body	Amplifier (Delco)																																					V	V	V																		
D	2007	(DP)CTS	Body	Climate Control Panel																																								V	V	V	V	V												
D	2007	(DP)CTS	Body	Dash Integration Module																																					V	V	V							V	V	V								
D	2007	(DP)CTS	Body	Digital Radio Receiver																																																							
D	2007	(DP)CTS	Body	Driver Door Switch																																					V	V																		
D	2007	(DP)CTS	Body	Driver Door Module																																					V	V	V							V		V								
D	2007	(DP)CTS	Body	Passenger Door Module																																					V	V	V							V		V								
D	2007	(DP)CTS	Body	Left Rear Door Module																																					V	V	V																	
D	2007	(DP)CTS	Body	Right Rear Door Module																																					V	V	V																	
D	2007	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																							
D	2007	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																							
D	2007	(DP)CTS	Body	Instrument Panel Cluster																																					V	V																		
D	2007	(DP)CTS	Body	Memory Seat Module																																					V	V	V												V	V				
D	2007	(DP)CTS	Body	Personalization																																																			V	V		
D	2007	(DP)CTS	Body	Rear Integration Module																																					V	V	V							V									V	
D	2007	(DP)CTS	Body	Remote Control Door Lock Receiver																																																						
D	2007	(DP)CTS	Body	Supplemental Inflatable Restraint																																					V																			V
D	2007	(DP)CTS	Body	Theft Deterrent Module																																					V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2007	(DP)CTS	Body	TV Antenna Module																																						V	V	V																
D	2007	(DP)CTS	Body	Vehicle Comm. Interface Module																																																								
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																											V	V	V	V																										
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																											V	V	V	V																										
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																						
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																											V	V	V	V																										
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																											V	V	V	V																										
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																						
D	2007	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																		V	V	V																				
D	2007	(DR)CTS	Chassis	VES																																																								
D	2007	(DR)CTS	Body	Amplifier (Bose)																																						V	V	V																
D	2007	(DR)CTS	Body	Amplifier (Delco)																																						V	V	V																
D	2007	(DR)CTS	Body	Climate Control Panel																																									V	V	V	V	V											
D	2007	(DR)CTS	Body	Dash Integration Module																																						V	V	V						V	V	V								
D	2007	(DR)CTS	Body	Digital Radio Receiver																																																								
D	2007	(DR)CTS	Body	Driver Door Switch																																						V	V																		
D	2007	(DR)CTS	Body	Driver Door Module																																						V	V	V							V		V								
D	2007	(DR)CTS	Body	Passenger Door Module																																						V	V	V							V		V								
D	2007	(DR)CTS	Body	Left Rear Door Module																																						V	V	V																	
D	2007	(DR)CTS	Body	Right Rear Door Module																																						V	V	V																
D	2007	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																								
D	2007	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																								
D	2007	(DR)CTS	Body	Instrument Panel Cluster																																						V	V																		
D	2007	(DR)CTS	Body	Memory Seat Module																																						V	V	V											V	V				
D	2007	(DR)CTS	Body	Personalization																																																				V	V			
D	2007	(DR)CTS	Body	Rear Integration Module																																						V	V	V							V									V	
D	2007	(DR)CTS	Body	Remote Control Door Lock Receiver																																																								
D	2007	(DR)CTS	Body	Supplemental Inflatable Restraint																																						V																		V
D	2007	(DR)CTS	Body	Theft Deterrent Module																																						V																		
D	2007	(DR)CTS	Body	TV Antenna Module																																						V	V	V																
D	2007	(DR)CTS	Body	Vehicle Comm. Interface Module																																																								
D	2007	(DN)CTS-V	Powertrain	(U)6.0L V8 LS2 Engine Control Module																											V		V	V																										
D	2007	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																		V	V	V																				
D	2007	(DN)CTS-V	Chassis	VES																																																								
D	2007	(DN)CTS-V	Body	Amplifier (Bose)																																						V	V	V																
D	2007	(DN)CTS-V	Body	Amplifier (Delco)																																						V	V	V																
D	2007	(DN)CTS-V	Body	Climate Control Panel																																									V	V	V	V	V											
D	2007	(DN)CTS-V	Body	Dash Integration Module																																						V	V	V						V	V	V								
D	2007	(DN)CTS-V	Body	Digital Radio Receiver																																																								
D	2007	(DN)CTS-V	Body	Driver Door Switch																																						V	V																	
D	2007	(DN)CTS-V	Body	Driver Door Module																																						V	V	V							V		V							
D	2007	(DN)CTS-V	Body	Passenger Door Module																																						V	V	V							V		V							
D	2007	(DN)CTS-V	Body	Left Rear Door Module																																						V	V	V																
D	2007	(DN)CTS-V	Body	Right Rear Door Module																																						V	V	V																
D	2007	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																								
D	2007	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																								
D	2007	(DN)CTS-V	Body	Instrument Panel Cluster																																						V	V																		
D	2007	(DN)CTS-V	Body	Memory Seat Module																																						V	V	V											V	V							
D	2007	(DN)CTS-V	Body	Personalization																																																				V	V			
D	2007	(DN)CTS-V	Body	Rear Integration Module																																						V	V	V							V									V	
D	2007	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2007	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																					V																			V
D	2007	(DN)CTS-V	Body	Theft Deterrent Module																																					V																			
D	2007	(DN)CTS-V	Body	TV Antenna Module																																					V	V	V																	
D	2007	(DN)CTS-V	Body	Vehicle Comm. Interface Module																																																								
D	2007	(DC)STS-V8	Powertrain	Engine Control Module																											V		V	V																										
D	2007	(DC)STS-V8	Powertrain	Transmission Control Module																																V	V																							
D	2007	(DC)STS-V8	Chassis	Electronic Brake Control Module																																			V																				
D	2007	(DC)STS-V8	Chassis	Electronic Suspension Control																																																							
D	2007	(DC)STS-V8	Body	Amplifier (Bose)																																																							
D	2007	(DC)STS-V8	Body	Digital Radio Receiver																																																							
D	2007	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																							
D	2007	(DC)STS-V8	Body	Driver Door Module																																					V																			
D	2007	(DC)STS-V8	Body	Driver Door Switch																																																							
D	2007	(DC)STS-V8	Body	Driver Position Module																																						V	V																	
D	2007	(DC)STS-V8	Body	Headlamp Control Module																																																							
D	2007	(DC)STS-V8	Body	Head Up Display																																																							
D	2007	(DC)STS-V8	Body	HVAC Control Module																																								V	V	V	V	V												
D	2007	(DC)STS-V8	Body	Instrument Panel Cluster																																																							
D	2007	(DC)STS-V8	Body	Instrument Panel Module																																						V	V																	
D	2007	(DC)STS-V8	Body	Left Rear Door Module																																					V																			
D	2007	(DC)STS-V8	Body	Passenger Door Module																																					V																			
D	2007	(DC)STS-V8	Body	Uplevel Radio																																																							
D	2007	(DC)STS-V8	Body	Navigation Radio																																																							
D	2007	(DC)STS-V8	Body	Rear Integration Module																																					V	V	V			V													
D	2007	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																					V																			
D	2007	(DC)STS-V8	Body	Right Rear Door Module																																					V																			
D	2007	(DC)STS-V8	Body	Steering Column Lock Module																																																							
D	2007	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																					V																			V
D	2007	(DC)STS-V8	Body	TV Antenna Module																																					V	V	V																	
D	2007	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																							
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V	V	V	V																										
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																					
D	2007	(DW)STS	Chassis	Electronic Brake Control Module																																			V																			
D	2007	(DW)STS	Chassis	Electronic Suspension Control																																																							
D	2007	(DW)STS	Body	Amplifier (Bose)																																																							
D	2007	(DW)STS	Body	Digital Radio Receiver																																																							
D	2007	(DW)STS	Body	Distance Sensing Cruise Control																																																							
D	2007	(DW)STS	Body	Driver Door Module																																					V																			
D	2007	(DW)STS	Body	Driver Door Switch																																																							
D	2007	(DW)STS	Body	Driver Position Module																																						V	V																	
D	2007	(DW)STS	Body	Headlamp Control Module																																																							
D	2007	(DW)STS	Body	Head Up Display																																																							
D	2007	(DW)STS	Body	HVAC Control Module																																								V	V	V	V	V												
D	2007	(DW)STS	Body	Instrument Panel Cluster																																																							
D	2007	(DW)STS	Body	Instrument Panel Module																																						V	V																	
D	2007	(DW)STS	Body	Left Rear Door Module																																					V																			
D	2007	(DW)STS	Body	Passenger Door Module																																					V																			
D	2007	(DW)STS	Body	Uplevel Radio																																																							
D	2007	(DW)STS	Body	Navigation Radio																																																							
D	2007	(DW)STS	Body	Rear Integration Module																																					V	V	V			V													
D	2007	(DW)STS	Body	Remote Control Door Lock Receiver																																					V																			

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2007	(DW)STS	Body	Right Rear Door Module																																					V																		
D	2007	(DW)STS	Body	Steering Column Lock Module																																																						
D	2007	(DW)STS	Body	Supplemental Inflatable Restraint																																					V																		V
D	2007	(DW)STS	Body	TV Antenna Module																																					V	V	V															
D	2007	(DW)STS	Body	Vehicle Comm. Interface Module																																																						
D	2007	(DX)STS-V	Powertrain	Engine Control Module																											V		V	V																										
D	2007	(DX)STS-V	Powertrain	Transmission Control Module																																V	V																						
D	2007	(DX)STS-V	Chassis	Electronic Brake Control Module																																			V																			
D	2007	(DX)STS-V	Chassis	Electronic Suspension Control																																																						
D	2007	(DX)STS-V	Body	Amplifier (Bose)																																																						
D	2007	(DX)STS-V	Body	Digital Radio Receiver																																																						
D	2007	(DX)STS-V	Body	Distance Sensing Cruise Control																																																						
D	2007	(DX)STS-V	Body	Driver Door Module																																					V																		
D	2007	(DX)STS-V	Body	Driver Door Switch																																																						
D	2007	(DX)STS-V	Body	Driver Position Module																																						V	V																
D	2007	(DX)STS-V	Body	Headlamp Control Module																																																						
D	2007	(DX)STS-V	Body	Head Up Display																																																						
D	2007	(DX)STS-V	Body	HVAC Control Module																																								V	V	V	V	V											
D	2007	(DX)STS-V	Body	Instrument Panel Cluster																																																						
D	2007	(DX)STS-V	Body	Instrument Panel Module																																						V	V																
D	2007	(DX)STS-V	Body	Left Rear Door Module																																					V																		
D	2007	(DX)STS-V	Body	Passenger Door Module																																					V																		
D	2007	(DX)STS-V	Body	Uplevel Radio																																																						
D	2007	(DX)STS-V	Body	Navigation Radio																																																						
D	2007	(DX)STS-V	Body	Rear Integration Module																																					V	V	V			V													
D	2007	(DX)STS-V	Body	Remote Control Door Lock Receiver																																					V																		
D	2007	(DX)STS-V	Body	Right Rear Door Module																																					V																		
D	2007	(DX)STS-V	Body	Steering Column Lock Module																																																						
D	2007	(DX)STS-V	Body	Supplemental Inflatable Restraint																																					V																		V
D	2007	(DX)STS-V	Body	TV Antenna Module																																					V	V	V															
D	2007	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																						
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																											V		V	V																										
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																V	V																						
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																											V		V	V																										
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																V	V																						
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																						
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																										
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																V	V																						
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																						
D	2008	CTS	Chassis	Electronic Brake Control Module																																			V																		
D	2008	CTS	Body	Body Control Module			V																																			V	V																
D	2008	CTS	Body	Body Control Module (aux.)																																																						
D	2008	CTS	Body	Driver Door Switch																																					V	V	V															
D	2008	CTS	Body	Headlamp Control Module																																																						
D	2008	CTS	Body	HVAC Control Module																																								V			V											
D	2008	CTS	Body	Infotainment Faceplate Module																																																						
D	2008	CTS	Body	Instrument Panel Cluster																																																						
D	2008	CTS	Body	Memory Seat Module																																																						
D	2008	CTS	Body	Park Assist Module																																																						
D	2008	CTS	Body	Passenger Door Switch																																					V	V	V															
D	2008	CTS	Body	Passenger Presence System																																					V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2008	CTS	Body	Pedestrian Impact Detection Module																																																									V
D	2008	CTS	Body	Radio																																					V																			
D	2008	CTS	Body	Supplemental Inflatable Restraint																																					V																			
D	2008	CTS	Body	TV Antenna Module																																					V	V	V																	
D	2008	CTS	Body	Vehicle Comm. Interface Module																																																								
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																											V	V	V	V																											
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																						
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V	V	V	V																											
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																						
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																											V		V	V																											
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																	V	V																						
D	2008	SLS	Chassis	Electronic Brake Control Module																																			V																					
D	2008	SLS	Chassis	Electronic Suspension Control																																																								
D	2008	SLS	Body	Amplifier (Bose)																																																								
D	2008	SLS	Body	Driver Door Module																																					V																			
D	2008	SLS	Body	Driver Door Switch																																																								
D	2008	SLS	Body	Driver Position Module																																						V	V																		
D	2008	SLS	Body	Headlamp Control Module																																																								
D	2008	SLS	Body	HVAC Control Module																																								V	V	V	V	V													
D	2008	SLS	Body	Instrument Panel Cluster																																																								
D	2008	SLS	Body	Instrument Panel Module																																						V	V																		
D	2008	SLS	Body	Left Rear Door Module																																					V																			
D	2008	SLS	Body	Passenger Door Module																																					V																			
D	2008	SLS	Body	Radio																																																								
D	2008	SLS	Body	Rear HVAC/RSA																																																								
D	2008	SLS	Body	Rear Integration Module																																					V	V	V			V														
D	2008	SLS	Body	Remote Control Door Lock Receiver																																					V																			
D	2008	SLS	Body	Right Rear Door Module																																					V																			
D	2008	SLS	Body	Supplemental Inflatable Restraint																																					V																			V
D	2008	SLS	Body	TV Antenna Module																																					V	V	V																	
D	2008	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																											V		V	V																											
D	2008	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																	V	V																						
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																											V		V	V																											
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																	V	V																						
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																											V		V	V																											
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																	V	V																						
D	2008	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																			V																					
D	2008	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																								
D	2008	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																								
D	2008	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																								
D	2008	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																			V																					
D	2008	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																								
D	2008	STS	Body	Amplifier (Bose)																																																								
D	2008	STS	Body	Digital Radio Receiver																																																								
D	2008	STS	Body	Distance Sensing Cruise Control																																																								
D	2008	STS	Body	Driver Door Module																																					V																			
D	2008	STS	Body	Driver Door Switch																																																								
D	2008	STS	Body	Driver Position Module																																						V	V																		
D	2008	STS	Body	Headlamp Control Module																																																								
D	2008	STS	Body	Head Up Display																																																								
D	2008	STS	Body	HVAC Control Module																																								V	V	V	V	V													

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2008	STS	Body	Instrument Panel Cluster																																																							
D	2008	STS	Body	Instrument Panel Module																																						V	V																
D	2008	STS	Body	Left Rear Door Module																																				V																			
D	2008	STS	Body	Left Side Object Detection Module																																																							
D	2008	STS	Body	Passenger Door Module																																				V																			
D	2008	STS	Body	Uplevel Radio																																																							
D	2008	STS	Body	Navigation Radio																																																							
D	2008	STS	Body	Rear Integration Module																																				V	V	V			V														
D	2008	STS	Body	Remote Control Door Lock Receiver																																				V																			
D	2008	STS	Body	Right Rear Door Module																																				V																			
D	2008	STS	Body	Right Side Object Detection Module																																																							
D	2008	STS	Body	Steering Column Lock Module																																																							
D	2008	STS	Body	Supplemental Inflatable Restraint																																				V																			V
D	2008	STS	Body	TV Antenna Module																																				V	V	V																		
D	2008	STS	Body	Vehicle Comm. Interface Module																																																							
D	2008	STS	Body	Veh Direction Alert Alarm Warn Mod																																																							
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																											V		V	V																										
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																											V		V	V																										
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																							
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																V	V																							
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																											V		V	V																										
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																V	V																							
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																											V		V	V																										
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																V	V																							
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																							
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																										
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																V	V																							
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																							
D	2009	CTS	Chassis	Electronic Brake Control Module																																			V																			
D	2009	CTS	Chassis	Electronic Suspension Control																																																							
D	2009	CTS	Chassis	Parking Brake Control Module																																																							
D	2009	CTS	Body	Body Control Module			V																																			V	V																
D	2009	CTS	Body	Body Control Module (aux.)																																																							
D	2009	CTS	Body	Driver Door Switch																																				V	V	V																	
D	2009	CTS	Body	Headlamp Control Module																																																							
D	2009	CTS	Body	HVAC Control Module																																							V			V														
D	2009	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																							
D	2009	CTS	Body	Instrument Panel Cluster (Other)																																																							
D	2009	CTS	Body	Memory Seat Module																																																							
D	2009	CTS	Body	Park Assist Module																																																							
D	2009	CTS	Body	Passenger Door Switch																																				V	V	V																	
D	2009	CTS	Body	Passenger Presence System																																				V																			
D	2009	CTS	Body	Pedestrian Impact Detection Module																																																							V
D	2009	CTS	Body	Radio																																				V																			
D	2009	CTS	Body	Supplemental Inflatable Restraint																																				V																			
D	2009	CTS	Body	TV Antenna Module																																				V	V	V																	
D	2009	CTS	Body	Vehicle Comm. Interface Module																																																							
D	2009	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																											V	V	V	V																										
D	2009	SLS	Powertrain	(T)2.8L V6 LP2 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																				
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V	V	V	V																										
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																				

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																											V		V	V																									
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																V	V																					
D	2009	SLS	Chassis	Electronic Brake Control Module																																			V																			
D	2009	SLS	Chassis	Electronic Suspension Control																																																					
D	2009	SLS	Body	Amplifier (Bose)																																																					
D	2009	SLS	Body	Driver Door Module																																					V																	
D	2009	SLS	Body	Driver Door Switch																																																					
D	2009	SLS	Body	Driver Position Module																																						V	V															
D	2009	SLS	Body	Headlamp Control Module																																																					
D	2009	SLS	Body	HVAC Control Module																																								V	V	V	V	V										
D	2009	SLS	Body	Instrument Panel Cluster																																																					
D	2009	SLS	Body	Instrument Panel Module																																						V	V															
D	2009	SLS	Body	Left Rear Door Module																																					V																	
D	2009	SLS	Body	Passenger Door Module																																					V																	
D	2009	SLS	Body	Radio																																																					
D	2009	SLS	Body	Rear HVAC/RSA																																																					
D	2009	SLS	Body	Rear Integration Module																																					V	V	V			V												
D	2009	SLS	Body	Remote Control Door Lock Receiver																																					V																	
D	2009	SLS	Body	Right Rear Door Module																																					V																	
D	2009	SLS	Body	Supplemental Inflatable Restraint																																					V																	V
D	2009	SLS	Body	TV Antenna Module																																					V	V	V															
D	2009	SLS	Body	Vehicle Comm. Interface Module																																																					
D	2009	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																											V		V	V																									
D	2009	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																V	V																					
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																											V		V	V																									
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																V	V																					
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																											V		V	V																									
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																V	V																					
D	2009	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																			V																		
D	2009	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																					
D	2009	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																					
D	2009	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																					
D	2009	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																			V																		
D	2009	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																					
D	2009	STS	Body	Amplifier (Bose)																																																					
D	2009	STS	Body	Digital Radio Receiver																																																					
D	2009	STS	Body	Distance Sensing Cruise Control																																																					
D	2009	STS	Body	Driver Door Module																																					V																	
D	2009	STS	Body	Driver Door Switch																																																					
D	2009	STS	Body	Driver Position Module																																						V	V															
D	2009	STS	Body	Headlamp Control Module																																																					
D	2009	STS	Body	Head Up Display																																																					
D	2009	STS	Body	HVAC Control Module																																								V	V	V	V	V										
D	2009	STS	Body	Instrument Panel Cluster																																																					
D	2009	STS	Body	Instrument Panel Module																																						V	V															
D	2009	STS	Body	Left Rear Door Module																																					V																	
D	2009	STS	Body	Left Side Object Detection Module																																																					
D	2009	STS	Body	Passenger Door Module																																					V																	
D	2009	STS	Body	Uplevel Radio																																																					
D	2009	STS	Body	Navigation Radio																																																					
D	2009	STS	Body	Rear Integration Module																																					V	V	V			V												

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2009	STS	Body	Remote Control Door Lock Receiver																																					V																			
D	2009	STS	Body	Right Rear Door Module																																					V																			
D	2009	STS	Body	Right Side Object Detection Module																																																								
D	2009	STS	Body	Steering Column Lock Module																																																								
D	2009	STS	Body	Supplemental Inflatable Restraint																																					V																			V
D	2009	STS	Body	TV Antenna Module																																					V	V	V																	
D	2009	STS	Body	Vehicle Comm. Interface Module																																																								
D	2009	STS	Body	Veh Direction Alert Alarm Warn Mod																																																								
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																											V		V	V																											
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																											V		V	V																											
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																								
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																	V	V																							
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Auto																											V	V	V	V																											
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Manual																											V	V	V	V																											
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transmission Control Module																																	V	V																							
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Fuel Pump Control Module																																																								
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transfer Case Control Module																																																								
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module Auto																											V	V	V	V																											
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																	V	V																							
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Fuel Pump Control Module																																																								
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																								
D	2010	CTS	Chassis	Electronic Brake Control Module																																			V																					
D	2010	CTS	Chassis	Electronic Suspension Control																																																								
D	2010	CTS	Chassis	Parking Brake Control Module																																																								
D	2010	CTS	Body	Body Control Module			V																																			V	V																	
D	2010	CTS	Body	Body Control Module (aux.)																																																								
D	2010	CTS	Body	Driver Door Switch																																					V	V	V																	
D	2010	CTS	Body	Headlamp Control Module																																																								
D	2010	CTS	Body	HVAC Control Module																																								V			V													
D	2010	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																								
D	2010	CTS	Body	Instrument Panel Cluster (Other)																																																								
D	2010	CTS	Body	Liftgate Module																																					V																			
D	2010	CTS	Body	Memory Seat Module																																																								
D	2010	CTS	Body	Park Assist Module																																																								
D	2010	CTS	Body	Passenger Door Switch																																					V	V	V																	
D	2010	CTS	Body	Passenger Presence System																																					V																			
D	2010	CTS	Body	Pedestrian Impact Detection Module																																																								V
D	2010	CTS	Body	Radio																																					V																			
D	2010	CTS	Body	Supplemental Inflatable Restraint																																																								
D	2010	CTS	Body	TV Antenna Module																																					V	V	V																	
D	2010	CTS	Body	Vehicle Comm. Interface Module																																																								
D	2010	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																											V	V	V	V																											
D	2010	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																	V	V																							
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																											V		V	V																											
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																	V	V																							
D	2010	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																				V																			
D	2010	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																								
D	2010	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																								
D	2010	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																								
D	2010	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																				V																			
D	2010	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2010	STS	Body	Amplifier (Bose)																																																							
D	2010	STS	Body	Digital Radio Receiver																																																							
D	2010	STS	Body	Distance Sensing Cruise Control																																																							
D	2010	STS	Body	Driver Door Module																																					V																			
D	2010	STS	Body	Driver Door Switch																																																							
D	2010	STS	Body	Driver Position Module																																						V	V																	
D	2010	STS	Body	Headlamp Control Module																																																							
D	2010	STS	Body	Head Up Display																																																							
D	2010	STS	Body	HVAC Control Module																																								V	V	V	V	V												
D	2010	STS	Body	Instrument Panel Cluster																																																							
D	2010	STS	Body	Instrument Panel Module																																						V	V																	
D	2010	STS	Body	Left Rear Door Module																																					V																			
D	2010	STS	Body	Left Side Object Detection Module																																																							
D	2010	STS	Body	Passenger Door Module																																					V																			
D	2010	STS	Body	Uplevel Radio																																																							
D	2010	STS	Body	Navigation Radio																																																							
D	2010	STS	Body	Rear Integration Module																																					V	V	V			V													
D	2010	STS	Body	Remote Control Door Lock Receiver																																					V																			
D	2010	STS	Body	Right Rear Door Module																																					V																			
D	2010	STS	Body	Right Side Object Detection Module																																																							
D	2010	STS	Body	Steering Column Lock Module																																																							
D	2010	STS	Body	Supplemental Inflatable Restraint																																					V																			V
D	2010	STS	Body	TV Antenna Module																																					V	V	V																	
D	2010	STS	Body	Vehicle Comm. Interface Module																																																							
D	2010	STS	Body	Veh Direction Alert Alarm Warn Mod																																																							
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																											V		V	V																									
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																											V		V	V																									
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																							
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																	V	V																					
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Auto																											V	V	V	V																									
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Manual																											V	V	V	V																									
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																	V	V																					
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																							
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transfer Case Control Module																																																							
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Engine Control Module																											V	V	V	V																									
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																	V	V																					
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Fuel Pump Control Module																																																							
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transfer Case Control Module																																																							
D	2011	CTS	Chassis	Electronic Brake Control Module																																			V																			
D	2011	CTS	Chassis	Electronic Suspension Control																																																							
D	2011	CTS	Chassis	Parking Brake Control Module																																																							
D	2011	CTS	Body	Body Control Module (6.2L V8 LSA)			V																																			V	V																
D	2011	CTS	Body	Body Control Module (Other)			V																																			V	V																
D	2011	CTS	Body	Body Control Module (aux.)																																																							
D	2011	CTS	Body	Driver Door Switch																																					V	V	V																
D	2011	CTS	Body	Headlamp Control Module																																																							
D	2011	CTS	Body	HVAC Control Module																																								V			V												
D	2011	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																							
D	2011	CTS	Body	Instrument Panel Cluster (Other)																																																							
D	2011	CTS	Body	Liftgate Module																																					V																		
D	2011	CTS	Body	Memory Seat Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2011	CTS	Body	Park Assist Module																																																								
D	2011	CTS	Body	Passenger Door Switch																																				V	V	V																	
D	2011	CTS	Body	Passenger Presence System																																				V																			
D	2011	CTS	Body	Pedestrian Impact Detection Module																																																							V
D	2011	CTS	Body	Radio																																				V																			
D	2011	CTS	Body	Supplemental Inflatable Restraint																																																						
D	2011	CTS	Body	TV Antenna Module																																				V	V	V																	
D	2011	CTS	Body	Vehicle Comm. Interface Module																																																						
D	2011	STS	Powertrain	(D)3.6L V6 LLT Engine Control Module																											V	V	V	V																										
D	2011	STS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																	V	V																					
D	2011	STS	Chassis	Electronic Brake Control Module																																			V																			
D	2011	STS	Chassis	Electronic Suspension Control																																																						
D	2011	STS	Body	Amplifier (Bose)																																																						
D	2011	STS	Body	Digital Radio Receiver																																																						
D	2011	STS	Body	Distance Sensing Cruise Control																																																						
D	2011	STS	Body	Driver Door Module																																				V																			
D	2011	STS	Body	Driver Door Switch																																																						
D	2011	STS	Body	Driver Position Module																																					V	V																	
D	2011	STS	Body	Headlamp Control Module																																																						
D	2011	STS	Body	Head Up Display																																																						
D	2011	STS	Body	HVAC Control Module																																							V	V	V	V	V												
D	2011	STS	Body	Instrument Panel Cluster																																																						
D	2011	STS	Body	Instrument Panel Module																																					V	V																	
D	2011	STS	Body	Left Rear Door Module																																				V																			
D	2011	STS	Body	Left Side Object Detection Module																																																						
D	2011	STS	Body	Passenger Door Module																																				V																			
D	2011	STS	Body	Uplevel Radio																																																						
D	2011	STS	Body	Navigation Radio																																																						
D	2011	STS	Body	Rear Integration Module																																				V	V	V			V													
D	2011	STS	Body	Remote Control Door Lock Receiver																																				V																			
D	2011	STS	Body	Right Rear Door Module																																				V																			
D	2011	STS	Body	Right Side Object Detection Module																																																						
D	2011	STS	Body	Supplemental Inflatable Restraint																																				V																			V
D	2011	STS	Body	TV Antenna Module																																				V	V	V																	
D	2011	STS	Body	Vehicle Comm. Interface Module																																																						
D	2011	STS	Body	Veh Direction Alert Alarm Warn Mod																																																						
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																											V		V	V																									
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																											V		V	V																									
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																						
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																	V	V																					
D	2012	P Type Engine	Chassis	Electronic Brake Control Module																																			V																			
D	2012	P Type Engine	Chassis	Electronic Suspension Control																																																						
D	2012	P Type Engine	Chassis	Parking Brake Control Module																																																						
D	2012	P Type Engine	Body	Body Control Module			V																																		V	V																	
D	2012	P Type Engine	Body	Body Control Module (aux.)																																																						
D	2012	P Type Engine	Body	Driver Door Switch																																				V	V	V																	
D	2012	P Type Engine	Body	Headlamp Control Module																																																						
D	2012	P Type Engine	Body	HVAC Control Module																																							V			V													
D	2012	P Type Engine	Body	Instrument Panel Cluster																																																						
D	2012	P Type Engine	Body	Left Side Object Detection Module																																																						
D	2012	P Type Engine	Body	Liftgate Module																																				V																			

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2012	P Type Engine	Body	Memory Seat Module																																																								
D	2012	P Type Engine	Body	Park Assist Module																																																								
D	2012	P Type Engine	Body	Passenger Door Switch																																					V	V	V																	
D	2012	P Type Engine	Body	Passenger Presence System																																					V																			
D	2012	P Type Engine	Body	Pedestrian Impact Detection Module																																																								V
D	2012	P Type Engine	Body	Radio																																					V																			
D	2012	P Type Engine	Body	Right Side Object Detection Module																																																								
D	2012	P Type Engine	Body	Supplemental Inflatable Restraint																																																								
D	2012	P Type Engine	Body	TV Antenna Module																																					V	V	V																	
D	2012	P Type Engine	Body	Vehicle Comm. Interface Module																																																								
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto																											V	V	V	V																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual																											V	V	V	V																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																								
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																	V	V																						
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																								
D	2012	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module																											V	V	V	V																										
D	2012	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																								
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																	V	V																						
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																								
D	2012	Other	Chassis	Electronic Brake Control Module																																			V																					
D	2012	Other	Chassis	Electronic Suspension Control																																																								
D	2012	Other	Chassis	Parking Brake Control Module																																																								
D	2012	Other	Body	Body Control Module			V																																			V	V																
D	2012	Other	Body	Body Control Module (aux.)																																																								
D	2012	Other	Body	Driver Door Switch																																					V	V	V																	
D	2012	Other	Body	Headlamp Control Module																																																								
D	2012	Other	Body	HVAC Control Module																																								V			V													
D	2012	Other	Body	Instrument Panel Cluster																																																								
D	2012	Other	Body	Left Side Object Detection Module																																																								
D	2012	Other	Body	Liftgate Module																																					V																			
D	2012	Other	Body	Memory Seat Module																																																								
D	2012	Other	Body	Park Assist Module																																																								
D	2012	Other	Body	Passenger Door Switch																																					V	V	V																	
D	2012	Other	Body	Passenger Presence System																																					V																			
D	2012	Other	Body	Pedestrian Impact Detection Module																																																								V
D	2012	Other	Body	Radio																																					V																			
D	2012	Other	Body	Right Side Object Detection Module																																																								
D	2012	Other	Body	Supplemental Inflatable Restraint																																																								
D	2012	Other	Body	TV Antenna Module																																					V	V	V																	
D	2012	Other	Body	Vehicle Comm. Interface Module																																																								
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																											V		V	V																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																											V		V	V																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																								
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																	V	V																						
D	2013	P Type Engine	Chassis	Electronic Brake Control Module																																			V																					
D	2013	P Type Engine	Chassis	Electronic Suspension Control																																																								
D	2013	P Type Engine	Chassis	Parking Brake Control Module																																																								
D	2013	P Type Engine	Body	Body Control Module			V																																			V	V																
D	2013	P Type Engine	Body	Body Control Module (aux.)																																																								
D	2013	P Type Engine	Body	Driver Door Switch																																					V	V	V																	
D	2013	P Type Engine	Body	Headlamp Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2013	P Type Engine	Body	HVAC Control Module																																							V				V											
D	2013	P Type Engine	Body	Instrument Panel Cluster																																																					
D	2013	P Type Engine	Body	Left Side Object Detection Module																																																					
D	2013	P Type Engine	Body	Liftgate Module																																					V																	
D	2013	P Type Engine	Body	Memory Seat Module																																																					
D	2013	P Type Engine	Body	Park Assist Module																																																					
D	2013	P Type Engine	Body	Passenger Door Switch																																					V	V	V															
D	2013	P Type Engine	Body	Passenger Presence System																																					V																	
D	2013	P Type Engine	Body	Pedestrian Impact Detection Module																																																					V
D	2013	P Type Engine	Body	Radio																																					V																	
D	2013	P Type Engine	Body	Right Side Object Detection Module																																																					
D	2013	P Type Engine	Body	Supplemental Inflatable Restraint																																																					
D	2013	P Type Engine	Body	TV Antenna Module																																					V	V	V															
D	2013	P Type Engine	Body	Vehicle Comm. Interface Module																																																					
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto																										V	V	V	V																									
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual																										V	V	V	V																									
D	2013	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																					
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																V	V																					
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																					
D	2013	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module																										V	V	V	V																									
D	2013	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																					
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																V	V																					
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																					
D	2013	Other	Chassis	Electronic Brake Control Module																																			V																			
D	2013	Other	Chassis	Electronic Suspension Control																																																					
D	2013	Other	Chassis	Parking Brake Control Module																																																					
D	2013	Other	Body	Body Control Module			V																																			V	V															
D	2013	Other	Body	Body Control Module (aux.)																																																					
D	2013	Other	Body	Driver Door Switch																																					V	V	V															
D	2013	Other	Body	Headlamp Control Module																																																					
D	2013	Other	Body	HVAC Control Module																																								V				V											
D	2013	Other	Body	Instrument Panel Cluster																																																					
D	2013	Other	Body	Left Side Object Detection Module																																																					
D	2013	Other	Body	Liftgate Module																																					V																	
D	2013	Other	Body	Memory Seat Module																																																					
D	2013	Other	Body	Park Assist Module																																																					
D	2013	Other	Body	Passenger Door Switch																																					V	V	V															
D	2013	Other	Body	Passenger Presence System																																					V																	
D	2013	Other	Body	Pedestrian Impact Detection Module																																																					V
D	2013	Other	Body	Radio																																					V																	
D	2013	Other	Body	Right Side Object Detection Module																																																					
D	2013	Other	Body	Supplemental Inflatable Restraint																																																					
D	2013	Other	Body	TV Antenna Module																																					V	V	V															
D	2013	Other	Body	Vehicle Comm. Interface Module																																																					
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																					
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																					
D	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																					
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																					
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																					
D	2014	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																					
D	2014	CTS	Powertrain	Chassis Control Module																																																					

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2014	CTS	Powertrain	Transfer Case Control Module																																																								
D	2014	CTS	Chassis	Electronic Brake Control Module																																																									
D	2014	CTS	Chassis	Parking Brake Control Module																																																									
D	2014	CTS	Chassis	Suspension Control Module																																																									
D	2014	CTS	Body	Body Control Module Coupe																																																									
D	2014	CTS	Body	Body Control Module Station Wagon																																																									
D	2014	CTS	Body	Auxiliary Body Control Module																																																									
D	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2014	CTS	Body	Passenger Presence Module																																																									
D	2014	CTS	Body	Pedestrian Impact Detection Module																																																									
D	2014	CTS	Body	Instrument Cluster																																																									
D	2014	CTS	Body	Headlamp Control Module																																																									
D	2014	CTS	Body	Radio																																																									
D	2014	CTS	Body	Amplifier																																																									
D	2014	CTS	Body	Television Antenna Module																																																									
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																									
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																									
D	2014	CTS	Body	HVAC Control Module																																																									
D	2014	CTS	Body	Driver Door Switch Panel Control Module																																																									
D	2014	CTS	Body	Passenger Door Switch Panel Control Module																																																									
D	2014	CTS	Body	Liftgate Control Module																																																									
D	2014	CTS	Body	Seat Memory Control Module																																																									
D	2014	CTS	Body	Right Side Object Detection Control Module																																																									
D	2014	CTS	Body	Left Side Object Detection Control Module																																																									
D	2014	CTS	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																									
D	2014	CTS	Body	Remote Control Keyless Type Standard Range (ATG)																																																									
D	2014	CTS	Body	Parking Assist Control Module																																																									
D	2014	CTS	Body	Theft Deterrent Module																																																									
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																									
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																									
D	2015	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																									
D	2015	CTS	Powertrain	Chassis Control Module																																																									
D	2015	CTS	Powertrain	Transfer Case Control Module																																																									
D	2015	CTS	Chassis	Electronic Brake Control Module																																																									
D	2015	CTS	Chassis	Parking Brake Control Module																																																									
D	2015	CTS	Chassis	Suspension Control Module																																																									
D	2015	CTS	Body	Body Control Module Coupe																																																									
D	2015	CTS	Body	Body Control Module Station Wagon																																																									
D	2015	CTS	Body	Auxiliary Body Control Module																																																									
D	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2015	CTS	Body	Passenger Presence Module																																																									
D	2015	CTS	Body	Pedestrian Impact Detection Module																																																									
D	2015	CTS	Body	Instrument Cluster																																																									
D	2015	CTS	Body	Headlamp Control Module																																																									
D	2015	CTS	Body	Radio																																																									
D	2015	CTS	Body	Amplifier																																																									
D	2015	CTS	Body	Television Antenna Module																																																									
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 9																																																									
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																									
D	2015	CTS	Body	HVAC Control Module																																																									
D	2015	CTS	Body	Driver Door Switch Panel Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2015	CTS	Body	Passenger Door Switch Panel Control Module																																																								
D	2015	CTS	Body	Liftgate Control Module																																																								
D	2015	CTS	Body	Seat Memory Control Module																																																								
D	2015	CTS	Body	Right Side Object Detection Control Module																																																								
D	2015	CTS	Body	Left Side Object Detection Control Module																																																								
D	2015	CTS	Body	Remote Control Door Lock Receiver																																																								
D	2015	CTS	Body	Parking Assist Control Module																																																								
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module													V	V	V																																									
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V																															
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module													V	V	V																																									
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V																															
K	2004	(KD)Deville	Body	Amplifier (Delco)																																					V	V	V																	
K	2004	(KD)Deville	Body	CD Changer																																																								
K	2004	(KD)Deville	Body	Dash Integration Module																																					V	V	V						V	V										
K	2004	(KD)Deville	Body	Digital Radio Receiver																																																								
K	2004	(KD)Deville	Body	Driver Door Switch																																					V	V																		
K	2004	(KD)Deville	Body	Driver Door Module																																					V	V	V						V											
K	2004	(KD)Deville	Body	Passenger Door Module																																					V	V	V						V											
K	2004	(KD)Deville	Body	Left Rear Door Module																																					V	V	V																	
K	2004	(KD)Deville	Body	Right Rear Door Module																																					V	V	V																	
K	2004	(KD)Deville	Body	Instrument Panel Cluster																																					V	V							V		V									
K	2004	(KD)Deville	Body	Instrument Panel Module																																								V			V	V		V		V								
K	2004	(KD)Deville	Body	Memory Seat Module																																					V	V	V								V		V	V						
K	2004	(KD)Deville	Body	Navigation Radio																																																							V	
K	2004	(KD)Deville	Body	Radio																																													V		V								V	
K	2004	(KD)Deville	Body	Rear Climate Control Panel																																								V			V				V								
K	2004	(KD)Deville	Body	Rear Integration Module																																					V	V	V						V											
K	2004	(KD)Deville	Body	Remote Function Actuation																																													V		V									
K	2004	(KD)Deville	Body	Supplemental Inflatable Restraint																																					V																		V	
K	2004	(KD)Deville	Body	Tilt Telescope Module																																					V										V									
K	2004	(KD)Deville	Body	Vehicle Theft Deterrent																																					V	V									V									
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module													V	V	V																																									
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V																															
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module													V	V	V																																									
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V																															
K	2004	(KE)DHS	Body	Amplifier (Bose)																																					V	V	V								V									
K	2004	(KE)DHS	Body	CD Changer																																																								
K	2004	(KE)DHS	Body	Dash Integration Module																																					V	V	V						V	V										
K	2004	(KE)DHS	Body	Digital Radio Receiver																																																								
K	2004	(KE)DHS	Body	Driver Door Switch																																					V	V																		
K	2004	(KE)DHS	Body	Driver Door Module																																					V	V	V						V											
K	2004	(KE)DHS	Body	Passenger Door Module																																					V	V	V						V											
K	2004	(KE)DHS	Body	Left Rear Door Module																																					V	V	V																	
K	2004	(KE)DHS	Body	Right Rear Door Module																																					V	V	V																	
K	2004	(KE)DHS	Body	Instrument Panel Cluster																																					V	V							V		V									
K	2004	(KE)DHS	Body	Instrument Panel Module																																								V			V	V		V		V								
K	2004	(KE)DHS	Body	Memory Seat Module																																					V	V	V								V		V	V						
K	2004	(KE)DHS	Body	Navigation Radio																																																							V	
K	2004	(KE)DHS	Body	Radio																																													V		V								V	
K	2004	(KE)DHS	Body	Rear Climate Control Panel																																								V			V				V								
K	2004	(KE)DHS	Body	Rear Integration Module																																					V	V	V						V											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2004	(KE)DHS	Body	Remote Function Actuation																																													V		V							
K	2004	(KE)DHS	Body	Supplemental Inflatable Restraint																																					V																	V
K	2004	(KE)DHS	Body	Tilt Telescope Module																																					V										V							
K	2004	(KE)DHS	Body	Vehicle Theft Deterrent																																					V	V									V							
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module													V	V	V																																							
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V																													
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module													V	V	V																																							
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V																													
K	2004	(KF)DTS	Body	Amplifier (Bose)																																					V	V	V								V							
K	2004	(KF)DTS	Body	CD Changer																																																						
K	2004	(KF)DTS	Body	Dash Integration Module																																					V	V	V							V	V							
K	2004	(KF)DTS	Body	Digital Radio Receiver																																																					
K	2004	(KF)DTS	Body	Driver Door Switch																																					V	V																
K	2004	(KF)DTS	Body	Driver Door Module																																					V	V	V							V								
K	2004	(KF)DTS	Body	Passenger Door Module																																					V	V	V							V								
K	2004	(KF)DTS	Body	Left Rear Door Module																																					V	V	V															
K	2004	(KF)DTS	Body	Right Rear Door Module																																					V	V	V															
K	2004	(KF)DTS	Body	Instrument Panel Cluster																																					V	V								V		V						
K	2004	(KF)DTS	Body	Instrument Panel Module																																								V			V	V		V		V						
K	2004	(KF)DTS	Body	Memory Seat Module																																					V	V	V									V		V	V				
K	2004	(KF)DTS	Body	Navigation Radio																																																						V
K	2004	(KF)DTS	Body	Radio																																													V		V							V
K	2004	(KF)DTS	Body	Rear Climate Control Panel																																							V			V					V							
K	2004	(KF)DTS	Body	Rear Integration Module																																					V	V	V							V								
K	2004	(KF)DTS	Body	Remote Function Actuation																																													V		V							
K	2004	(KF)DTS	Body	Supplemental Inflatable Restraint																																					V																	V
K	2004	(KF)DTS	Body	Tilt Telescope Module																																					V										V							
K	2004	(KF)DTS	Body	Vehicle Theft Deterrent																																					V	V									V							
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Engine Control Module													V	V	V																																							
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V																													
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module													V	V	V																																							
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V																													
K	2004	(KS)Seville SLS	Body	Amplifier (Bose)																																					V	V	V								V							
K	2004	(KS)Seville SLS	Body	Amplifier (Delco)																																					V	V	V															
K	2004	(KS)Seville SLS	Body	CD Changer																																																					
K	2004	(KS)Seville SLS	Body	Dash Integration Module																																					V	V	V							V	V							
K	2004	(KS)Seville SLS	Body	Digital Radio Receiver																																																					
K	2004	(KS)Seville SLS	Body	Driver Door Module																																					V	V	V							V								
K	2004	(KS)Seville SLS	Body	Instrument Panel Cluster																																					V	V								V		V						
K	2004	(KS)Seville SLS	Body	Instrument Panel Module																																								V			V	V		V		V						
K	2004	(KS)Seville SLS	Body	Memory Seat Module																																					V	V	V									V		V	V				
K	2004	(KS)Seville SLS	Body	Navigation Radio																																																						V
K	2004	(KS)Seville SLS	Body	Radio																																													V		V							V
K	2004	(KS)Seville SLS	Body	Rear Integration Module																																					V	V	V															
K	2004	(KS)Seville SLS	Body	Remote Function Actuation																																													V		V							
K	2004	(KS)Seville SLS	Body	Supplemental Inflatable Restraint																																					V	V																
K	2004	(KS)Seville SLS	Body	Tilt Telescope Module																																					V										V							
K	2004	(KS)Seville SLS	Body	Vehicle Theft Deterrent																																					V	V									V							
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Engine Control Module													V	V	V																																							
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V																													
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module													V	V	V																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V																															
K	2004	(KY)Seville STS	Body	Amplifier (Bose)																																					V	V	V									V							
K	2004	(KY)Seville STS	Body	Amplifier (Delco)																																					V	V	V																
K	2004	(KY)Seville STS	Body	CD Changer																																																							
K	2004	(KY)Seville STS	Body	Dash Integration Module																																					V	V	V							V	V									
K	2004	(KY)Seville STS	Body	Digital Radio Receiver																																																							
K	2004	(KY)Seville STS	Body	Driver Door Module																																					V	V	V							V										
K	2004	(KY)Seville STS	Body	Instrument Panel Cluster																																					V	V								V		V							
K	2004	(KY)Seville STS	Body	Instrument Panel Module																																								V			V	V		V		V							
K	2004	(KY)Seville STS	Body	Memory Seat Module																																					V	V	V									V		V	V				
K	2004	(KY)Seville STS	Body	Navigation Radio																																																							V
K	2004	(KY)Seville STS	Body	Radio																																														V		V							V
K	2004	(KY)Seville STS	Body	Rear Integration Module																																					V	V	V																
K	2004	(KY)Seville STS	Body	Remote Function Actuation																																														V		V							
K	2004	(KY)Seville STS	Body	Supplemental Inflatable Restraint																																					V	V																	
K	2004	(KY)Seville STS	Body	Tilt Telescope Module																																					V											V							
K	2004	(KY)Seville STS	Body	Vehicle Theft Deterrent																																					V	V										V							
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module													V	V	V																																								
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V																															
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module													V	V	V																																								
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V																															
K	2005	(KD)Deville	Body	Amplifier (Delco)																																					V	V	V																
K	2005	(KD)Deville	Body	CD Changer																																																							
K	2005	(KD)Deville	Body	Dash Integration Module																																					V	V	V							V	V									
K	2005	(KD)Deville	Body	Digital Radio Receiver																																																							
K	2005	(KD)Deville	Body	Driver Door Switch																																					V	V																	
K	2005	(KD)Deville	Body	Driver Door Module																																					V	V	V							V									
K	2005	(KD)Deville	Body	Passenger Door Module																																					V	V	V							V									
K	2005	(KD)Deville	Body	Left Rear Door Module																																					V	V	V																
K	2005	(KD)Deville	Body	Right Rear Door Module																																					V	V	V																
K	2005	(KD)Deville	Body	Instrument Panel Cluster																																					V	V								V		V							
K	2005	(KD)Deville	Body	Instrument Panel Module																																								V			V	V		V		V							
K	2005	(KD)Deville	Body	Memory Seat Module																																					V	V	V									V		V	V				
K	2005	(KD)Deville	Body	Navigation Radio																																																						V
K	2005	(KD)Deville	Body	Radio																																														V		V							V
K	2005	(KD)Deville	Body	Rear Climate Control Panel																																							V			V					V								
K	2005	(KD)Deville	Body	Rear Integration Module																																					V	V	V							V									
K	2005	(KD)Deville	Body	Remote Function Actuation																																													V		V							
K	2005	(KD)Deville	Body	Supplemental Inflatable Restraint																																					V																		V
K	2005	(KD)Deville	Body	Tilt Telescope Module																																					V											V							
K	2005	(KD)Deville	Body	Vehicle Theft Deterrent																																					V	V										V							
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module													V	V	V																																								
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V																															
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module													V	V	V																																								
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V																															
K	2005	(KE)DHS	Body	Amplifier (Bose)																																					V	V	V									V							
K	2005	(KE)DHS	Body	CD Changer																																																						
K	2005	(KE)DHS	Body	Dash Integration Module																																					V	V	V							V	V									
K	2005	(KE)DHS	Body	Digital Radio Receiver																																																						
K	2005	(KE)DHS	Body	Driver Door Switch																																					V	V																	
K	2005	(KE)DHS	Body	Driver Door Module																																					V	V	V							V									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2005	(KE)DHS	Body	Passenger Door Module																																						V	V	V						V										
K	2005	(KE)DHS	Body	Left Rear Door Module																																						V	V	V																
K	2005	(KE)DHS	Body	Right Rear Door Module																																						V	V	V																
K	2005	(KE)DHS	Body	Instrument Panel Cluster																																						V	V							V		V								
K	2005	(KE)DHS	Body	Instrument Panel Module																																									V			V	V		V		V							
K	2005	(KE)DHS	Body	Memory Seat Module																																						V	V	V									V		V	V				
K	2005	(KE)DHS	Body	Navigation Radio																																																								V
K	2005	(KE)DHS	Body	Radio																																															V		V							V
K	2005	(KE)DHS	Body	Rear Climate Control Panel																																								V				V				V							
K	2005	(KE)DHS	Body	Rear Integration Module																																						V	V	V						V										
K	2005	(KE)DHS	Body	Remote Function Actuation																																														V		V							
K	2005	(KE)DHS	Body	Supplemental Inflatable Restraint																																						V																		V
K	2005	(KE)DHS	Body	Tilt Telescope Module																																						V										V								
K	2005	(KE)DHS	Body	Vehicle Theft Deterrent																																						V	V									V								
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module													V	V	V																																								
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V																															
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module													V	V	V																																								
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V																															
K	2005	(KF)DTS	Body	Amplifier (Bose)																																						V	V	V								V								
K	2005	(KF)DTS	Body	CD Changer																																																							
K	2005	(KF)DTS	Body	Dash Integration Module																																						V	V	V						V	V									
K	2005	(KF)DTS	Body	Digital Radio Receiver																																																							
K	2005	(KF)DTS	Body	Driver Door Switch																																						V	V																	
K	2005	(KF)DTS	Body	Driver Door Module																																						V	V	V						V										
K	2005	(KF)DTS	Body	Passenger Door Module																																						V	V	V						V										
K	2005	(KF)DTS	Body	Left Rear Door Module																																						V	V	V																
K	2005	(KF)DTS	Body	Right Rear Door Module																																						V	V	V																
K	2005	(KF)DTS	Body	Instrument Panel Cluster																																						V	V							V		V								
K	2005	(KF)DTS	Body	Instrument Panel Module																																									V			V	V		V		V							
K	2005	(KF)DTS	Body	Memory Seat Module																																						V	V	V								V		V	V				
K	2005	(KF)DTS	Body	Navigation Radio																																																								V
K	2005	(KF)DTS	Body	Radio																																															V		V							V
K	2005	(KF)DTS	Body	Rear Climate Control Panel																																								V			V					V							
K	2005	(KF)DTS	Body	Rear Integration Module																																						V	V	V						V										
K	2005	(KF)DTS	Body	Remote Function Actuation																																														V		V							
K	2005	(KF)DTS	Body	Supplemental Inflatable Restraint																																						V																		V
K	2005	(KF)DTS	Body	Tilt Telescope Module																																						V										V								
K	2005	(KF)DTS	Body	Vehicle Theft Deterrent																																						V	V									V								
K	2006	ALL	Powertrain	Engine Control Module																											V		V																												
K	2006	ALL	Powertrain	Automatic Transaxle																V	V	V		V	V	V	V		V								V	V																						
K	2006	ALL	Chassis	Antilock Brake System																																			V																				
K	2006	ALL	Body	Amplifier (Bose)																																																							
K	2006	ALL	Body	Aux. HVAC Control Module																																																							
K	2006	ALL	Body	Body Control Module			V																																				V	V																
K	2006	ALL	Body	Digital Radio Receiver																																																							
K	2006	ALL	Body	Distance Sensing Cruise Control																																																							
K	2006	ALL	Body	Driver Door Switch																																						V	V	V																
K	2006	ALL	Body	Driver Position Module																																																							
K	2006	ALL	Body	HVAC Control Module																																									V			V												
K	2006	ALL	Body	Instrument Panel Cluster																																																							
K	2006	ALL	Body	Park Assist Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2006	ALL	Body	Passenger Door Switch																																					V	V	V																	
K	2006	ALL	Body	Passenger Presence System																																					V																			
K	2006	ALL	Body	Radio																																																								
K	2006	ALL	Body	Rear Heated Seat Module																																																								
K	2006	ALL	Body	Remote Control Door Lock Receiver																																																								
K	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																			
K	2006	ALL	Body	Theft Deterrent Module																																																								
K	2006	ALL	Body	TV Antenna Module																																					V	V	V																		
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2007	ALL	Powertrain	Engine Control Module																											V		V	V																											
K	2007	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V	V																						
K	2007	ALL	Chassis	Electronic Brake Control Module																																			V																					
K	2007	ALL	Body	Amplifier (Bose)																																																								
K	2007	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																								
K	2007	ALL	Body	Body Control Module			V																																			V	V																	
K	2007	ALL	Body	Digital Radio Receiver																																																								
K	2007	ALL	Body	Distance Sensing Cruise Control																																																								
K	2007	ALL	Body	Driver Door Switch																																					V	V	V																		
K	2007	ALL	Body	Driver Position Module																																																								
K	2007	ALL	Body	CJ2 Dual Zone HVAC Auto																																								V				V													
K	2007	ALL	Body	CJ4 Tri Zone HVAC Auto																																								V				V												
K	2007	ALL	Body	Inside Rear View Mirror Module																																																								
K	2007	ALL	Body	Instrument Panel Cluster																																																								
K	2007	ALL	Body	Park Assist Module																																																								
K	2007	ALL	Body	Passenger Door Switch																																					V	V	V																		
K	2007	ALL	Body	Passenger Presence System																																					V																			
K	2007	ALL	Body	Radio																																																								
K	2007	ALL	Body	Rear Heated Seat Module																																																								
K	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																			
K	2007	ALL	Body	Theft Deterrent Module																																																								
K	2007	ALL	Body	TV Antenna Module																																					V	V	V																		
K	2007	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2008	ALL	Powertrain	Engine Control Module																											V		V	V																											
K	2008	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V	V																						
K	2008	ALL	Chassis	Electronic Brake Control Module																																				V																			
K	2008	ALL	Body	Amplifier (Bose)																																																								
K	2008	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																								
K	2008	ALL	Body	Body Control Module			V																																			V	V																	
K	2008	ALL	Body	Digital Radio Receiver																																																								
K	2008	ALL	Body	Distance Sensing Cruise Control																																																								
K	2008	ALL	Body	Driver Door Switch																																					V	V	V																		
K	2008	ALL	Body	Driver Position Module																																																								
K	2008	ALL	Body	CJ2 Dual Zone HVAC Auto																																								V				V													
K	2008	ALL	Body	CJ4 Tri Zone HVAC Auto																																								V				V												
K	2008	ALL	Body	Inside Rear View Mirror Module																																																								
K	2008	ALL	Body	Instrument Panel Cluster																																																								
K	2008	ALL	Body	Left Side Object Detection Module																																																								
K	2008	ALL	Body	Park Assist Module																																																								
K	2008	ALL	Body	Passenger Door Switch																																					V	V	V																		
K	2008	ALL	Body	Passenger Presence System																																					V																			
K	2008	ALL	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2008	ALL	Body	Rear Heated Seat Module																																																								
K	2008	ALL	Body	Right Side Object Detection Module																																																								
K	2008	ALL	Body	Supplemental Inflatable Restraint																																					V																			
K	2008	ALL	Body	Theft Deterrent Module																																																								
K	2008	ALL	Body	TV Antenna Module																																					V	V	V																	
K	2008	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2008	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																								
K	2009	ALL	Powertrain	Engine Control Module																											V		V	V																										
K	2009	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V	V																						
K	2009	ALL	Chassis	Electronic Brake Control Module																																			V																					
K	2009	ALL	Body	Amplifier (Bose)																																																								
K	2009	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																								
K	2009	ALL	Body	Body Control Module		V																																				V	V																	
K	2009	ALL	Body	Digital Radio Receiver																																																								
K	2009	ALL	Body	Distance Sensing Cruise Control																																																								
K	2009	ALL	Body	Driver Door Switch																																					V	V	V																	
K	2009	ALL	Body	Driver Position Module																																																								
K	2009	ALL	Body	CJ2 Dual Zone HVAC Auto																																								V			V													
K	2009	ALL	Body	CJ4 Tri Zone HVAC Auto																																								V			V													
K	2009	ALL	Body	Inside Rear View Mirror Module																																																								
K	2009	ALL	Body	Instrument Panel Cluster																																																								
K	2009	ALL	Body	Left Side Object Detection Module																																																								
K	2009	ALL	Body	Park Assist Module																																																								
K	2009	ALL	Body	Passenger Door Switch																																					V	V	V																	
K	2009	ALL	Body	Passenger Presence System																																					V																			
K	2009	ALL	Body	Radio																																																								
K	2009	ALL	Body	Rear Heated Seat Module																																																								
K	2009	ALL	Body	Right Side Object Detection Module																																																								
K	2009	ALL	Body	Supplemental Inflatable Restraint																																					V																			
K	2009	ALL	Body	Theft Deterrent Module																																																								
K	2009	ALL	Body	TV Antenna Module																																					V	V	V																	
K	2009	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2009	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2009	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																								
K	2010	ALL	Powertrain	Engine Control Module																											V		V	V																										
K	2010	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V	V																						
K	2010	ALL	Chassis	Electronic Brake Control Module																																			V																					
K	2010	ALL	Body	Amplifier (Bose)																																																								
K	2010	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																								
K	2010	ALL	Body	Body Control Module		V																																				V	V																	
K	2010	ALL	Body	Digital Radio Receiver																																																								
K	2010	ALL	Body	Distance Sensing Cruise Control																																																								
K	2010	ALL	Body	Driver Door Switch																																					V	V	V																	
K	2010	ALL	Body	Driver Position Module																																																								
K	2010	ALL	Body	CJ2 Dual Zone HVAC Auto																																								V			V													
K	2010	ALL	Body	CJ4 Tri Zone HVAC Auto																																								V			V													
K	2010	ALL	Body	Inside Rear View Mirror Module																																																								
K	2010	ALL	Body	Instrument Panel Cluster																																																								
K	2010	ALL	Body	Left Side Object Detection Module																																																								
K	2010	ALL	Body	Park Assist Module																																																								
K	2010	ALL	Body	Passenger Door Switch																																					V	V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2010	ALL	Body	Passenger Presence System																																					V																			
K	2010	ALL	Body	Radio																																																								
K	2010	ALL	Body	Rear Heated Seat Module																																																								
K	2010	ALL	Body	Right Side Object Detection Module																																																								
K	2010	ALL	Body	Supplemental Inflatable Restraint																																					V																			
K	2010	ALL	Body	Theft Deterrent Module																																																								
K	2010	ALL	Body	TV Antenna Module																																					V	V	V																	
K	2010	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2010	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																								
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Engine Control Module																											V		V	V																										
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V								V																							
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Engine Control Module																											V		V	V																										
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V								V																							
K	2011	ALL	Chassis	Electronic Brake Control Module																																			V																			
K	2011	ALL	Body	Amplifier (Bose)																																																								
K	2011	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																								
K	2011	ALL	Body	Body Control Module			V																																			V	V																	
K	2011	ALL	Body	Digital Radio Receiver																																																								
K	2011	ALL	Body	Distance Sensing Cruise Control																																																								
K	2011	ALL	Body	Driver Door Switch																																					V	V	V																	
K	2011	ALL	Body	Driver Position Module																																																								
K	2011	ALL	Body	CJ2 Dual Zone HVAC Auto																																								V				V												
K	2011	ALL	Body	CJ4 Tri Zone HVAC Auto																																								V				V												
K	2011	ALL	Body	Inside Rear View Mirror Module																																																								
K	2011	ALL	Body	Instrument Panel Cluster																																																								
K	2011	ALL	Body	Left Side Object Detection Module																																																								
K	2011	ALL	Body	Park Assist Module																																																								
K	2011	ALL	Body	Passenger Door Switch																																					V	V	V																	
K	2011	ALL	Body	Passenger Presence System																																					V																			
K	2011	ALL	Body	Radio																																																								
K	2011	ALL	Body	Rear Heated Seat Module																																																								
K	2011	ALL	Body	Right Side Object Detection Module																																																								
K	2011	ALL	Body	Supplemental Inflatable Restraint																																					V																			
K	2011	ALL	Body	Theft Deterrent Module																																																								
K	2011	ALL	Body	TV Antenna Module																																					V	V	V																	
K	2011	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2011	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																								
K	2016	CT6	Powertrain	(X) 2.0L LTG Engine Control Module																																																								
K	2016	CT6	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
K	2016	CT6	Powertrain	(6) 3.0L LGW Engine Control Module																																																								
K	2016	CT6	Powertrain	(6) 3.0L LGW Transmission Control Module																																																								
K	2016	CT6	Powertrain	(S) 3.6L LGX Engine Control Module																																																								
K	2016	CT6	Powertrain	(S) 3.6L LGX Transmission Control Module																																																								
K	2016	CT6	Powertrain	Transfer Case Control Module																																																								
K	2016	CT6	Chassis	Electronic Brake Control Module																																																								
K	2016	CT6	Chassis	Brake Booster Control Module																																																								
K	2016	CT6	Chassis	Power Steering Control Module																																																								
K	2016	CT6	Chassis	Rear Wheel Steering Control Module																																																								
K	2016	CT6	Chassis	Suspension Control Module																																																								
K	2016	CT6	Body	Body Control Module																																																								
K	2016	CT6	Body	Serial Data Gateway Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2016	CT6	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2016	CT6	Body	Passenger Presence Module																																																										
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Left				V	V																																																					
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Right				V	V																																																					
K	2016	CT6	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
K	2016	CT6	Body	Instrument Cluster Full Screen Display (UDV)																																																										
K	2016	CT6	Body	Radio Controls																																																										
K	2016	CT6	Body	HVAC Controls																																																										
K	2016	CT6	Body	Active Safety Control Module	V																																																									
K	2016	CT6	Body	Video Processing Control Module								V	V	V	V	V																																															
K	2016	CT6	Body	Headlamp Control Module																																																											
K	2016	CT6	Body	Trailer Interface Control Module																																																											
K	2016	CT6	Body	Radio																																																										
K	2016	CT6	Body	Amplifier																																																										
K	2016	CT6	Body	Infotainment Control Touchpad																																																										
K	2016	CT6	Body	Human Machine Interface Control Module																																																										
K	2016	CT6	Body	Navigation Control Module																																																										
K	2016	CT6	Body	Telematics Communication Interface Control Module																																																										
K	2016	CT6	Body	HVAC Control Module																																																										
K	2016	CT6	Body	Liftgate Control Module																																																										
K	2016	CT6	Body	Seat Memory Control Module - Passenger																																																										
K	2016	CT6	Body	Seat Memory Control Module - Left Rear																																																										
K	2016	CT6	Body	Seat Memory Control Module - Driver																																																										
K	2016	CT6	Body	Seat Memory Control Module - Right Rear																																																										
K	2016	CT6	Body	Keyless Entry Control Module																																																										
K	2016	CT6	Body	Left Side Object Detection Control Module																																																										
K	2016	CT6	Body	Parking Assist Control Module																																																										
K	2016	CT6	Body	Frontview Camera Module																																																										
K	2016	CT6	Body	Long Range Radar Sensor Module		V																																																								
K	2016	CT6	Body	Left Front Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Right Front Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Rear Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Night Vision Camera Control Module																																																										
R	2014	ELR	Powertrain	Engine Control Module																																																										
R	2014	ELR	Powertrain	Trasmission Control Module																																																										
R	2014	ELR	Powertrain	Chassis Control Module																																																										
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module																																																										
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2014	ELR	Powertrain	Drive Motor Control Module 1																																																										
R	2014	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2014	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2014	ELR	Chassis	Electronic Brake Control Module																																																										
R	2014	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2014	ELR	Chassis	Parking Brake Control Module																																																										
R	2014	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2014	ELR	Chassis	Power Steering Control Module																																																										
R	2014	ELR	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2014	ELR	Chassis	Suspension Control Module																																																										
R	2014	ELR	Body	Body Control Module			V																																																						
R	2014	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2014	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2014	ELR	Body	Passenger Presence Module																																																									
R	2014	ELR	Body	Instrument Cluster																																																									
R	2014	ELR	Body	Radio/HVAC Control																																																									
R	2014	ELR	Body	Radio																																																									
R	2014	ELR	Body	Amplifier																																																									
R	2014	ELR	Body	Human Machine Interface Control Module																																																										
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	ELR	Body	HVAC Control Module																																																										
R	2014	ELR	Body	Electric A/C Compressor Control Module																																																										
R	2014	ELR	Body	Coolant Heater Control Module																																																										
R	2014	ELR	Body	Seat Memory Control Module - Driver																																																										
R	2014	ELR	Body	Keyless Entry Control Module																																																										
R	2014	ELR	Body	Right Side Object Detection Control Module																																																										
R	2014	ELR	Body	Left Side Object Detection Control Module																																																										
R	2014	ELR	Body	Parking Assist Control Module																																																										
R	2014	ELR	Body	Frontview Camera Module																																																										
R	2014	ELR	Body	Steering Column Lock Control Module																																																										
R	2014	ELR	Body	Battery Charger Control Module																																																										
R	2014	ELR	Body	Battery Energy Control Module																																																										
R	2015	ELR	Powertrain	Engine Control Module																																																										
R	2015	ELR	Powertrain	Trasmission Control Module																																																										
R	2015	ELR	Powertrain	Chassis Control Module																																																										
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module																																																										
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2015	ELR	Powertrain	Drive Motor Control Module 1																																																										
R	2015	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2015	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2015	ELR	Chassis	Electronic Brake Control Module																																																										
R	2015	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2015	ELR	Chassis	Parking Brake Control Module																																																										
R	2015	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2015	ELR	Chassis	Power Steering Control Module																																																										
R	2015	ELR	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2015	ELR	Chassis	Suspension Control Module																																																										
R	2015	ELR	Body	Body Control Module			V																																																						
R	2015	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2015	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	ELR	Body	Passenger Presence Module																																																										
R	2015	ELR	Body	Instrument Cluster																																																										
R	2015	ELR	Body	Radio/HVAC Control																																																										
R	2015	ELR	Body	Headlamp Control Module																																																										
R	2015	ELR	Body	Radio																																																										
R	2015	ELR	Body	Amplifier																																																										
R	2015	ELR	Body	Human Machine Interface Control Module																																																										
R	2015	ELR	Body	Telematics Communication Interface Control Module																																																										
R	2015	ELR	Body	HVAC Control Module																																																										
R	2015	ELR	Body	Electric A/C Compressor Control Module																																																										
R	2015	ELR	Body	Coolant Heater Control Module																																																										
R	2015	ELR	Body	Seat Memory Control Module - Driver																																																										
R	2015	ELR	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2015	ELR	Body	Right Side Object Detection Control Module																																																									
R	2015	ELR	Body	Left Side Object Detection Control Module																																																										
R	2015	ELR	Body	Parking Assist Control Module																																																										
R	2015	ELR	Body	Frontview Camera Module																																																										
R	2015	ELR	Body	Steering Column Lock Control Module																																																										
R	2015	ELR	Body	Battery Charger Control Module																																																										
R	2015	ELR	Body	Battery Energy Control Module																																																										
R	2016	ELR	Powertrain	Engine Control Module																																																										
R	2016	ELR	Powertrain	Trasmission Control Module																																																										
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module																																																										
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2016	ELR	Powertrain	Drive Motor Control Module 1																																																										
R	2016	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2016	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2016	ELR	Chassis	Electronic Brake Control Module																																																										
R	2016	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2016	ELR	Chassis	Parking Brake Control Module																																																										
R	2016	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2016	ELR	Chassis	Power Steering Control Module																																																										
R	2016	ELR	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2016	ELR	Chassis	Suspension Control Module																																																										
R	2016	ELR	Body	Body Control Module			V																																																						
R	2016	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2016	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	ELR	Body	Passenger Presence Module																																																										
R	2016	ELR	Body	Instrument Cluster																																																										
R	2016	ELR	Body	Radio/HVAC Control																																																										
R	2016	ELR	Body	Headlamp Control Module																																																										
R	2016	ELR	Body	Radio																																																										
R	2016	ELR	Body	Amplifier																																																										
R	2016	ELR	Body	Human Machine Interface Control Module																																																										
R	2016	ELR	Body	Telematics Communication Interface Control Module																																																										
R	2016	ELR	Body	HVAC Control Module																																																										
R	2016	ELR	Body	Electric A/C Compressor Control Module																																																										
R	2016	ELR	Body	Coolant Heater Control Module																																																										
R	2016	ELR	Body	Seat Memory Control Module - Driver																																																										
R	2016	ELR	Body	Keyless Entry Control Module																																																										
R	2016	ELR	Body	Left Side Object Detection Control Module																																																										
R	2016	ELR	Body	Parking Assist Control Module																																																										
R	2016	ELR	Body	Frontview Camera Module																																																										
R	2016	ELR	Body	Steering Column Lock Control Module																																																										
R	2016	ELR	Body	Battery Charger Control Module																																																										
R	2016	ELR	Body	Battery Energy Control Module																																																										
Y	2004	ALL	Powertrain	Engine Control Module													V														V		V		V																												
Y	2004	ALL	Powertrain	Automatic Transmission																V	V	V	V		V	V	V	V								V	V	V																						
Y	2004	ALL	Chassis	Electronic Brake Control Module																																				V																					
Y	2004	ALL	Chassis	Electronic Suspension Control																																																										
Y	2004	ALL	Chassis	Steering Wheel and Column																																																										
Y	2004	ALL	Body	Amplifier (Bose)																																																										
Y	2004	ALL	Body	Body Control Module			V																																																						
Y	2004	ALL	Body	CD Changer																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Y	2004	ALL	Body	Digital Radio Receiver																																																								
Y	2004	ALL	Body	Distance Sensing Cruise Control																																																								
Y	2004	ALL	Body	Driver Door Module																																																								
Y	2004	ALL	Body	Driver Door Switch																																																								
Y	2004	ALL	Body	Driver Position Module																																						V	V																	
Y	2004	ALL	Body	Folding Top Module																																						V	V																	
Y	2004	ALL	Body	Head Up Display																																																								
Y	2004	ALL	Body	HVAC Control Module																																														V										
Y	2004	ALL	Body	Instrument Panel Cluster																																																								
Y	2004	ALL	Body	Navigation Radio																																																								
Y	2004	ALL	Body	Passenger Door Module																																																								
Y	2004	ALL	Body	Remote Control Door Lock Receiver																																					V																			
Y	2004	ALL	Body	Steering Column Lock Module																																																								
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2005	ALL	Powertrain	Engine Control Module												V														V		V		V																										
Y	2005	ALL	Powertrain	Automatic Transmission															V	V	V	V		V	V	V	V							V	V	V																							
Y	2005	ALL	Chassis	Electronic Brake Control Module																																			V																					
Y	2005	ALL	Chassis	Electronic Suspension Control																																																								
Y	2005	ALL	Chassis	Steering Wheel and Column																																																								
Y	2005	ALL	Body	Amplifier (Bose)																																																								
Y	2005	ALL	Body	Body Control Module			V																																																					
Y	2005	ALL	Body	CD Changer																																																								
Y	2005	ALL	Body	Digital Radio Receiver																																																								
Y	2005	ALL	Body	Distance Sensing Cruise Control																																																								
Y	2005	ALL	Body	Driver Door Module																																																								
Y	2005	ALL	Body	Driver Door Switch																																																								
Y	2005	ALL	Body	Driver Position Module																																						V	V																	
Y	2005	ALL	Body	Folding Top Module																																						V	V																	
Y	2005	ALL	Body	Head Up Display																																																								
Y	2005	ALL	Body	HVAC Control Module																																														V										
Y	2005	ALL	Body	Instrument Panel Cluster																																																								
Y	2005	ALL	Body	Navigation Radio																																																								
Y	2005	ALL	Body	Passenger Door Module																																																								
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																					V																			
Y	2005	ALL	Body	Steering Column Lock Module																																																								
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
Y	2006	(YV)XLR	Powertrain	Engine Control Module												V														V		V		V																										
Y	2006	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																								
Y	2006	(YV)XLR	Powertrain	Automatic Transmission															V	V	V	V		V	V	V	V							V	V	V																							
Y	2006	(YV)XLR	Chassis	Electronic Brake Control Module																																			V																					
Y	2006	(YV)XLR	Chassis	Electronic Suspension Control																																																								
Y	2006	(YV)XLR	Chassis	Steering Wheel and Column																																																								
Y	2006	(YV)XLR	Body	Amplifier (Bose)																																																								
Y	2006	(YV)XLR	Body	Body Control Module			V																																																					
Y	2006	(YV)XLR	Body	CD Changer																																																								
Y	2006	(YV)XLR	Body	Digital Radio Receiver																																																								
Y	2006	(YV)XLR	Body	Distance Sensing Cruise Control																																																								
Y	2006	(YV)XLR	Body	Driver Door Module																																																								
Y	2006	(YV)XLR	Body	Driver Door Switch																																																								
Y	2006	(YV)XLR	Body	Driver Position Module																																						V	V																	
Y	2006	(YV)XLR	Body	Folding Top Module																																						V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Y	2006	(YV)XLR	Body	Headlamp Control Module																																						V	V																
Y	2006	(YV)XLR	Body	Head Up Display																																																							
Y	2006	(YV)XLR	Body	HVAC Control Module																																													V									
Y	2006	(YV)XLR	Body	Instrument Panel Cluster																																																						
Y	2006	(YV)XLR	Body	Navigation Radio																																																						
Y	2006	(YV)XLR	Body	Passenger Door Module																																																						
Y	2006	(YV)XLR	Body	Remote Control Door Lock Receiver																																					V																		
Y	2006	(YV)XLR	Body	Steering Column Lock Module																																																						
Y	2006	(YV)XLR	Body	Supplemental Inflatable Restraint																																					V																		V
Y	2006	(YX)XLR-V	Powertrain	Engine Control Module																											V		V																										
Y	2006	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																						
Y	2006	(YX)XLR-V	Powertrain	Automatic Transmission																																																						
Y	2006	(YX)XLR-V	Chassis	Electronic Brake Control Module																																		V																				
Y	2006	(YX)XLR-V	Chassis	Electronic Suspension Control																																																						
Y	2006	(YX)XLR-V	Chassis	Steering Wheel and Column																																																						
Y	2006	(YX)XLR-V	Body	Amplifier (Bose)																																																						
Y	2006	(YX)XLR-V	Body	Body Control Module			V																																																				
Y	2006	(YX)XLR-V	Body	CD Changer																																																						
Y	2006	(YX)XLR-V	Body	Digital Radio Receiver																																																						
Y	2006	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																						
Y	2006	(YX)XLR-V	Body	Driver Door Module																																																						
Y	2006	(YX)XLR-V	Body	Driver Door Switch																																																						
Y	2006	(YX)XLR-V	Body	Driver Position Module																																						V	V																
Y	2006	(YX)XLR-V	Body	Folding Top Module																																						V	V																
Y	2006	(YX)XLR-V	Body	Headlamp Control Module																																						V	V																
Y	2006	(YX)XLR-V	Body	Head Up Display																																																						
Y	2006	(YX)XLR-V	Body	HVAC Control Module																																													V									
Y	2006	(YX)XLR-V	Body	Instrument Panel Cluster																																																						
Y	2006	(YX)XLR-V	Body	Navigation Radio																																																						
Y	2006	(YX)XLR-V	Body	Passenger Door Module																																																						
Y	2006	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																					V																	
Y	2006	(YX)XLR-V	Body	Steering Column Lock Module																																																						
Y	2006	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																					V																		V
Y	2007	(YV)XLR	Powertrain	Engine Control Module																											V		V	V																										
Y	2007	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																						
Y	2007	(YV)XLR	Powertrain	Transmission Control Module																																V	V																						
Y	2007	(YV)XLR	Chassis	Electronic Brake Control Module																																		V																				
Y	2007	(YV)XLR	Chassis	Electronic Suspension Control																																																						
Y	2007	(YV)XLR	Body	Amplifier (Bose)																																																						
Y	2007	(YV)XLR	Body	Body Control Module			V																																																			
Y	2007	(YV)XLR	Body	CD Changer																																																						
Y	2007	(YV)XLR	Body	Digital Radio Receiver																																																						
Y	2007	(YV)XLR	Body	Distance Sensing Cruise Control																																																						
Y	2007	(YV)XLR	Body	Driver Door Module																																																						
Y	2007	(YV)XLR	Body	Driver Door Switch																																																						
Y	2007	(YV)XLR	Body	Driver Position Module																																						V	V																
Y	2007	(YV)XLR	Body	Folding Top Module																																						V	V																
Y	2007	(YV)XLR	Body	Headlamp Control Module																																						V	V																
Y	2007	(YV)XLR	Body	Head Up Display																																																						
Y	2007	(YV)XLR	Body	HVAC Control Module																																													V									
Y	2007	(YV)XLR	Body	Instrument Panel Cluster																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Y	2007	(YV)XLR	Body	Navigation Radio																																																								
Y	2007	(YV)XLR	Body	Passenger Door Module																																																								
Y	2007	(YV)XLR	Body	Remote Control Door Lock Receiver																																				V																				
Y	2007	(YV)XLR	Body	Steering Column Lock Module																																																							
Y	2007	(YV)XLR	Body	Supplemental Inflatable Restraint																																				V																				V
Y	2007	(YX)XLR-V	Powertrain	Engine Control Module																											V		V	V																										
Y	2007	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																							
Y	2007	(YX)XLR-V	Powertrain	Transmission Control Module																																V	V																							
Y	2007	(YX)XLR-V	Chassis	Electronic Brake Control Module																																		V																				
Y	2007	(YX)XLR-V	Chassis	Electronic Suspension Control																																																							
Y	2007	(YX)XLR-V	Body	Amplifier (Bose)																																																							
Y	2007	(YX)XLR-V	Body	Body Control Module			V																																																				
Y	2007	(YX)XLR-V	Body	CD Changer																																																							
Y	2007	(YX)XLR-V	Body	Digital Radio Receiver																																																							
Y	2007	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																							
Y	2007	(YX)XLR-V	Body	Driver Door Module																																																							
Y	2007	(YX)XLR-V	Body	Driver Door Switch																																																							
Y	2007	(YX)XLR-V	Body	Driver Position Module																																						V	V																	
Y	2007	(YX)XLR-V	Body	Folding Top Module																																						V	V																	
Y	2007	(YX)XLR-V	Body	Headlamp Control Module																																						V	V																	
Y	2007	(YX)XLR-V	Body	Head Up Display																																																							
Y	2007	(YX)XLR-V	Body	HVAC Control Module																																														V										
Y	2007	(YX)XLR-V	Body	Instrument Panel Cluster																																																						
Y	2007	(YX)XLR-V	Body	Navigation Radio																																																							
Y	2007	(YX)XLR-V	Body	Passenger Door Module																																																							
Y	2007	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																				V																			
Y	2007	(YX)XLR-V	Body	Steering Column Lock Module																																																							
Y	2007	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																				V																				V
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																											V		V	V																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																							
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																V	V																							
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																											V		V	V																										
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																V	V																							
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																							
Y	2008	ALL	Chassis	Electronic Suspension Control																																																							
Y	2008	ALL	Body	Amplifier (Bose)																																																							
Y	2008	ALL	Body	Body Control Module			V																																																				
Y	2008	ALL	Body	CD Changer																																																							
Y	2008	ALL	Body	Digital Radio Receiver																																																							
Y	2008	ALL	Body	Distance Sensing Cruise Control																																																							
Y	2008	ALL	Body	Driver Door Module																																																							
Y	2008	ALL	Body	Driver Door Switch																																																							
Y	2008	ALL	Body	Driver Position Module																																						V	V																	
Y	2008	ALL	Body	Folding Top Module																																						V	V																	
Y	2008	ALL	Body	Headlamp Control Module																																						V	V																	
Y	2008	ALL	Body	Head Up Display																																																							
Y	2008	ALL	Body	HVAC Control Module																																												V										
Y	2008	ALL	Body	Instrument Panel Cluster																																																							
Y	2008	ALL	Body	Navigation Radio																																																							
Y	2008	ALL	Body	Passenger Door Module																																																							
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																				V																			

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Y	2008	ALL	Body	Steering Column Lock Module																																																								
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																					V																				V
Y	2008	ALL	Body	Vehicle Comm. Interface Module																																																								
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																										V		V	V																											
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																								
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																V	V																							
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																										V		V	V																											
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																V	V																							
Y	2009	ALL	Chassis	Electronic Brake Control Module																																		V																						
Y	2009	ALL	Chassis	Electronic Suspension Control																																																								
Y	2009	ALL	Body	Amplifier (Bose)																																																								
Y	2009	ALL	Body	Body Control Module			V																																																					
Y	2009	ALL	Body	CD Changer																																																								
Y	2009	ALL	Body	Digital Radio Receiver																																																								
Y	2009	ALL	Body	Distance Sensing Cruise Control																																																								
Y	2009	ALL	Body	Driver Door Module																																																								
Y	2009	ALL	Body	Driver Door Switch																																																								
Y	2009	ALL	Body	Driver Position Module																																						V	V																		
Y	2009	ALL	Body	Folding Top Module																																						V	V																		
Y	2009	ALL	Body	Headlamp Control Module																																						V	V																		
Y	2009	ALL	Body	Head Up Display																																																								
Y	2009	ALL	Body	HVAC Control Module																																														V										
Y	2009	ALL	Body	Instrument Panel Cluster																																																								
Y	2009	ALL	Body	Navigation Radio																																																								
Y	2009	ALL	Body	Passenger Door Module																																																								
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																					V																				
Y	2009	ALL	Body	Steering Column Lock Module																																																								
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																					V																				V
1	2013	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
1	2013	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
1	2013	XTS	Powertrain	Fuel Pump Control Module																																																								
1	2013	XTS	Powertrain	Rear Differential Clutch Control Module																																																								
1	2013	XTS	Chassis	Electronic Brake Control Module																																																								
1	2013	XTS	Chassis	Parking Brake Control Module																																																								
1	2013	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																								
1	2013	XTS	Chassis	Power Steering Control Module																																																								
1	2013	XTS	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2013	XTS	Chassis	Suspension Control Module																																																								
1	2013	XTS	Body	Body Control Module																																																								
1	2013	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2013	XTS	Body	Passenger Presence Module																																																								
1	2013	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																								
1	2013	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																								
1	2013	XTS	Body	Radio/HVAC Control																																																								
1	2013	XTS	Body	Active Safety Control Module	V																																																							
1	2013	XTS	Body	Headlamp Control Module																																																								
1	2013	XTS	Body	Radio																																																								
1	2013	XTS	Body	Amplifier																																																								
1	2013	XTS	Body	Human Machine Interface Control Module																																																								
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 9																																																								
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 10																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2013	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2013	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																									
1	2013	XTS	Body	Seat Memory Control Module																																																									
1	2013	XTS	Body	Keyless Entry Control Module																																																									
1	2013	XTS	Body	Right Side Object Detection Control Module																																																									
1	2013	XTS	Body	Left Side Object Detection Control Module																																																									
1	2013	XTS	Body	Parking Assist Control Module																																																									
1	2013	XTS	Body	Frontview Camera Module																																																									
1	2013	XTS	Body	Long Range Radar Sensor Module		V																																																							
1	2013	XTS	Body	Left Front Short Range Radar Sensor Module																																																									
1	2013	XTS	Body	Right Front Short Range Radar Sensor Module																																																									
1	2013	XTS	Body	Rear Short Range Radar Sensor Module																																																									
1	2014	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																									
1	2014	XTS	Powertrain	(8) 3.6L LF3 Chassis Control Module																																																									
1	2014	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																									
1	2014	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
1	2014	XTS	Powertrain	(3) 3.6L LFX Chassis Control Module																																																									
1	2014	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
1	2014	XTS	Powertrain	Rear Differential Clutch Control Module																																																									
1	2014	XTS	Chassis	Electronic Brake Control Module																																																									
1	2014	XTS	Chassis	Parking Brake Control Module																																																									
1	2014	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																									
1	2014	XTS	Chassis	Power Steering Control Module																																																									
1	2014	XTS	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2014	XTS	Chassis	Suspension Control Module																																																									
1	2014	XTS	Body	Body Control Module																																																									
1	2014	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2014	XTS	Body	Passenger Presence Module																																																									
1	2014	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																									
1	2014	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																									
1	2014	XTS	Body	Radio/HVAC Control																																																									
1	2014	XTS	Body	Active Safety Control Module	V																																																								
1	2014	XTS	Body	Headlamp Control Module																																																									
1	2014	XTS	Body	Radio																																																									
1	2014	XTS	Body	Amplifier																																																									
1	2014	XTS	Body	Media Disc Player																																																									
1	2014	XTS	Body	Human Machine Interface Control Module																																																									
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 9																																																									
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2014	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2014	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																									
1	2014	XTS	Body	Seat Memory Control Module - Passenger																																																									
1	2014	XTS	Body	Seat Memory Control Module - Driver																																																									
1	2014	XTS	Body	Keyless Entry Control Module																																																									
1	2014	XTS	Body	Right Side Object Detection Control Module																																																									
1	2014	XTS	Body	Left Side Object Detection Control Module																																																									
1	2014	XTS	Body	Parking Assist Control Module																																																									
1	2014	XTS	Body	Frontview Camera Module																																																									
1	2014	XTS	Body	Long Range Radar Sensor Module		V																																																							
1	2014	XTS	Body	Left Front Short Range Radar Sensor Module																																																									
1	2014	XTS	Body	Right Front Short Range Radar Sensor Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2014	XTS	Body	Rear Short Range Radar Sensor Module																																																										
1	2015	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
1	2015	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
1	2015	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2015	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2015	XTS	Powertrain	Chassis Control Module																																																											
1	2015	XTS	Powertrain	Rear Differential Clutch Control Module																																																											
1	2015	XTS	Chassis	Electronic Brake Control Module																																																											
1	2015	XTS	Chassis	Parking Brake Control Module																																																											
1	2015	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2015	XTS	Chassis	Power Steering Control Module																																																											
1	2015	XTS	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2015	XTS	Chassis	Suspension Control Module																																																											
1	2015	XTS	Body	Body Control Module																																																											
1	2015	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	XTS	Body	Passenger Presence Module																																																											
1	2015	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
1	2015	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																											
1	2015	XTS	Body	Radio/HVAC Control																																																											
1	2015	XTS	Body	Active Safety Control Module	V																																																										
1	2015	XTS	Body	Radio																																																											
1	2015	XTS	Body	Amplifier																																																											
1	2015	XTS	Body	Media Disc Player																																																											
1	2015	XTS	Body	Human Machine Interface Control Module																																																											
1	2015	XTS	Body	Telematics Communication Interface Control Module																																																											
1	2015	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2015	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
1	2015	XTS	Body	Seat Memory Control Module - Passenger																																																											
1	2015	XTS	Body	Seat Memory Control Module - Driver																																																											
1	2015	XTS	Body	Keyless Entry Control Module																																																											
1	2015	XTS	Body	Right Side Object Detection Control Module																																																											
1	2015	XTS	Body	Left Side Object Detection Control Module																																																											
1	2015	XTS	Body	Parking Assist Control Module GMLAN																																																											
1	2015	XTS	Body	Parking Assist Control Module DID72History																																																											
1	2015	XTS	Body	Frontview Camera Module																																																											
1	2015	XTS	Body	Long Range Radar Sensor Module		V																																																									
1	2015	XTS	Body	Left Front Short Range Radar Sensor Module																																																											
1	2015	XTS	Body	Right Front Short Range Radar Sensor Module																																																											
1	2015	XTS	Body	Rear Short Range Radar Sensor Module																																																											
1	2016	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
1	2016	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
1	2016	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2016	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2016	XTS	Powertrain	Chassis Control Module																																																											
1	2016	XTS	Powertrain	Rear Differential Clutch Control Module																																																											
1	2016	XTS	Chassis	Electronic Brake Control Module																																																											
1	2016	XTS	Chassis	Parking Brake Control Module																																																											
1	2016	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2016	XTS	Chassis	Power Steering Control Module																																																											
1	2016	XTS	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	XTS	Chassis	Suspension Control Module																																																											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2016	XTS	Body	Body Control Module																																																								
1	2016	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2016	XTS	Body	Passenger Presence Module																																																								
1	2016	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																								
1	2016	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																								
1	2016	XTS	Body	Radio/HVAC Control																																																								
1	2016	XTS	Body	Active Safety Control Module	V																																																							
1	2016	XTS	Body	Video Processing Control Module								V	V	V	V	V																																													
1	2016	XTS	Body	Radio																																																								
1	2016	XTS	Body	Amplifier																																																								
1	2016	XTS	Body	Media Disc Player																																																								
1	2016	XTS	Body	Human Machine Interface Control Module																																																								
1	2016	XTS	Body	Telematics Communication Interface Control Module																																																								
1	2016	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
1	2016	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																								
1	2016	XTS	Body	Seat Memory Control Module - Passenger																																																								
1	2016	XTS	Body	Seat Memory Control Module - Driver																																																								
1	2016	XTS	Body	Keyless Entry Control Module																																																								
1	2016	XTS	Body	Right Side Object Detection Control Module																																																								
1	2016	XTS	Body	Left Side Object Detection Control Module																																																								
1	2016	XTS	Body	Parking Assist Control Module																																																								
1	2016	XTS	Body	Frontview Camera Module																																																								
1	2016	XTS	Body	Steering Column Lock Control Module																																																								
1	2016	XTS	Body	Long Range Radar Sensor Module		V																																																						
1	2016	XTS	Body	Left Front Short Range Radar Sensor Module																																																								
1	2016	XTS	Body	Right Front Short Range Radar Sensor Module																																																								
1	2016	XTS	Body	Rear Short Range Radar Sensor Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Engine Mount																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Engine Mount																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Engine Mount																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2013	ATS	Powertrain	Transfer Case Control Module																																																										
A	2013	ATS	Chassis	Electronic Brake Control Module																																																										
A	2013	ATS	Chassis	Parking Brake Control Module																																																										
A	2013	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	ATS	Chassis	Power Steering Control Module																																																										
A	2013	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	ATS	Chassis	Suspension Control Module																																																										
A	2013	ATS	Body	Body Control Module Halogen																																																										
A	2013	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2013	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	ATS	Body	Passenger Presence Module																																																										
A	2013	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2013	ATS	Body	Instrument Cluster																																																										
A	2013	ATS	Body	Radio/HVAC Control																																																										
A	2013	ATS	Body	Active Safety Control Module																																																										
A	2013	ATS	Body	Headlamp Control Module																																																										
A	2013	ATS	Body	Trailer Interface Control Module																																																										
A	2013	ATS	Body	Radio																																																										
A	2013	ATS	Body	Amplifier																																																										
A	2013	ATS	Body	Human Machine Interface Control Module																																																										
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2013	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2013	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2013	ATS	Body	Seat Memory Control Module																																																										
A	2013	ATS	Body	Keyless Entry Type Without Passive Entry																																																										
A	2013	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
A	2013	ATS	Body	Right Side Object Detection Control Module																																																										
A	2013	ATS	Body	Left Side Object Detection Control Module																																																										
A	2013	ATS	Body	Parking Assist Control Module																																																										
A	2013	ATS	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2013	ATS	Body	Steering Column Lock Control Module																																																										
A	2013	ATS	Body	Long Range Radar Sensor Module																																																											
A	2013	ATS	Body	Left Front Short Range Radar Sensor Module																																																											
A	2013	ATS	Body	Right Front Short Range Radar Sensor Module																																																											
A	2013	ATS	Body	Rear Short Range Radar Sensor Module																																																											
A	2014	ATS	Powertrain	(X) 2.0L LTG Engine Control Module																																																											
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																											
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																											
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2014	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
A	2014	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																											
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																											
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																											
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2014	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
A	2014	ATS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																											
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																											
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2014	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
A	2014	ATS	Powertrain	Transfer Case Control Module																																																												
A	2014	ATS	Chassis	Electronic Brake Control Module																																																											
A	2014	ATS	Chassis	Parking Brake Control Module																																																											
A	2014	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2014	ATS	Chassis	Power Steering Control Module																																																											
A	2014	ATS	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2014	ATS	Chassis	Suspension Control Module																																																											
A	2014	ATS	Body	Body Control Module Halogen																																																											
A	2014	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
A	2014	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2014	ATS	Body	Passenger Presence Module																																																											
A	2014	ATS	Body	Pedestrian Impact Detection Module																																																											
A	2014	ATS	Body	Instrument Cluster																																																											
A	2014	ATS	Body	Radio/HVAC Control																																																											
A	2014	ATS	Body	Active Safety Control Module																																																											
A	2014	ATS	Body	Headlamp Control Module																																																											
A	2014	ATS	Body	Trailer Interface Control Module																																																											
A	2014	ATS	Body	Radio																																																											
A	2014	ATS	Body	Amplifier																																																											
A	2014	ATS	Body	Media Disc Player																																																											
A	2014	ATS	Body	Human Machine Interface Control Module																																																											
A	2014	ATS	Body	Navigation Control Module																																																											
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2014	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
A	2014	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
A	2014	ATS	Body	Seat Memory Control Module - Driver																																																											
A	2014	ATS	Body	Keyless Entry Type Without Passive Entry																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2014	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
A	2014	ATS	Body	Right Side Object Detection Control Module																																																											
A	2014	ATS	Body	Left Side Object Detection Control Module																																																											
A	2014	ATS	Body	Parking Assist Control Module																																																											
A	2014	ATS	Body	Frontview Camera Module																																																											
A	2014	ATS	Body	Steering Column Lock Control Module																																																											
A	2014	ATS	Body	Long Range Radar Sensor Module																																																											
A	2014	ATS	Body	Left Front Short Range Radar Sensor Module																																																											
A	2014	ATS	Body	Right Front Short Range Radar Sensor Module																																																											
A	2014	ATS	Body	Rear Short Range Radar Sensor Module																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Maunal Transmission																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
A	2014	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
A	2014	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																											
A	2014	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
A	2014	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2014	CTS	Powertrain	Transfer Case Control Module																																																											
A	2014	CTS	Chassis	Electronic Brake Control Module																																																											
A	2014	CTS	Chassis	Parking Brake Control Module																																																											
A	2014	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2014	CTS	Chassis	Power Steering Control Module																																																											
A	2014	CTS	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2014	CTS	Chassis	Suspension Control Module																																																											
A	2014	CTS	Body	Body Control Module Headlamp Type Halogen																																																											
A	2014	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
A	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2014	CTS	Body	Passenger Presence Module																																																											
A	2014	CTS	Body	Pedestrian Impact Detection Module																																																											
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Left																																																											
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Right																																																											
A	2014	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
A	2014	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																											
A	2014	CTS	Body	Radio/HVAC Control																																																											
A	2014	CTS	Body	Active Safety Control Module																																																											
A	2014	CTS	Body	Headlamp Control Module																																																											
A	2014	CTS	Body	Trailer Interface Control Module																																																											
A	2014	CTS	Body	Radio																																																											
A	2014	CTS	Body	Amplifier																																																										
A	2014	CTS	Body	Human Machine Interface Control Module																																																											
A	2014	CTS	Body	Navigation Control Module																																																											
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2014	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2014	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2014	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2014	CTS	Body	Keyless Entry Control Module																																																										
A	2014	CTS	Body	Right Side Object Detection Control Module																																																										
A	2014	CTS	Body	Left Side Object Detection Control Module																																																										
A	2014	CTS	Body	Parking Assist Control Module																																																										
A	2014	CTS	Body	Frontview Camera Module																																																										
A	2014	CTS	Body	Steering Column Lock Control Module																																																										
A	2014	CTS	Body	Long Range Radar Sensor Module																																																										
A	2014	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2014	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2014	CTS	Body	Rear Short Range Radar Sensor Module																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2015	ATS	Powertrain	Transfer Case Control Module																																																										
A	2015	ATS	Chassis	Electronic Brake Control Module																																																										
A	2015	ATS	Chassis	Parking Brake Control Module																																																										
A	2015	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	ATS	Chassis	Power Steering Control Module																																																										
A	2015	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	ATS	Chassis	Suspension Control Module																																																										
A	2015	ATS	Body	Body Control Module Halogen																																																										
A	2015	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2015	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	ATS	Body	Passenger Presence Module																																																										
A	2015	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2015	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2015	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2015	ATS	Body	Radio/HVAC Control																																																										
A	2015	ATS	Body	Active Safety Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2015	ATS	Body	Headlamp Control Module																																																										
A	2015	ATS	Body	Trailer Interface Control Module																																																										
A	2015	ATS	Body	Radio																																																										
A	2015	ATS	Body	Amplifier																																																										
A	2015	ATS	Body	Media Disc Player																																																										
A	2015	ATS	Body	Human Machine Interface Control Module																																																										
A	2015	ATS	Body	Navigation Control Module																																																										
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2015	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2015	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2015	ATS	Body	Seat Memory Control Module - Driver																																																										
A	2015	ATS	Body	Keyless Entry Control Module Coupe																																																										
A	2015	ATS	Body	Keyless Entry Control Module Sadan																																																										
A	2015	ATS	Body	Right Side Object Detection Control Module																																																										
A	2015	ATS	Body	Left Side Object Detection Control Module																																																										
A	2015	ATS	Body	Parking Assist Control Module																																																										
A	2015	ATS	Body	Frontview Camera Module																																																										
A	2015	ATS	Body	Steering Column Lock Control Module																																																										
A	2015	ATS	Body	Long Range Radar Sensor Module																																																										
A	2015	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2015	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2015	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Engine Mount																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Engine Mount																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																										
A	2015	CTS	Powertrain	Transfer Case Control Module																																																										
A	2015	CTS	Chassis	Electronic Brake Control Module																																																										
A	2015	CTS	Chassis	Parking Brake Control Module																																																										
A	2015	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	CTS	Chassis	Power Steering Control Module																																																										
A	2015	CTS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	CTS	Chassis	Suspension Control Module																																																										
A	2015	CTS	Body	Body Control Module Headlamp Type Halogen																																																										
A	2015	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	CTS	Body	Passenger Presence Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2015	CTS	Body	Pedestrian Impact Detection Module																																																										
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2015	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2015	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2015	CTS	Body	Active Safety Control Module																																																										
A	2015	CTS	Body	Trailer Interface Control Module																																																										
A	2015	CTS	Body	Radio																																																										
A	2015	CTS	Body	Amplifier																																																										
A	2015	CTS	Body	Human Machine Interface Control Module																																																										
A	2015	CTS	Body	Navigation Control Module																																																										
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2015	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2015	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2015	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2015	CTS	Body	Keyless Entry Control Module																																																										
A	2015	CTS	Body	Right Side Object Detection Control Module																																																										
A	2015	CTS	Body	Left Side Object Detection Control Module																																																										
A	2015	CTS	Body	Parking Assist Control Module																																																										
A	2015	CTS	Body	Frontview Camera Module																																																										
A	2015	CTS	Body	Steering Column Lock Control Module																																																										
A	2015	CTS	Body	Long Range Radar Sensor Module																																																										
A	2015	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2015	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2015	CTS	Body	Rear Short Range Radar Sensor Module																																																										
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2016	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
A	2016	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Automatic Transmission																																																										
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Manual Transmission																																																										
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Transmission Control Module																																																										
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																										
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																										
A	2016	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2016	ATS	Powertrain	Transfer Case Control Module																																																										
A	2016	ATS	Powertrain	Rear Differential Clutch Control Module																																																										
A	2016	ATS	Chassis	Electronic Brake Control Module																																																										
A	2016	ATS	Chassis	Parking Brake Control Module																																																										
A	2016	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2016	ATS	Chassis	Power Steering Control Module																																																										
A	2016	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	ATS	Chassis	Suspension Control Module																																																										
A	2016	ATS	Body	Body Control Module Halogen																																																										
A	2016	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2016	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	ATS	Body	Passenger Presence Module																																																										
A	2016	ATS	Body	Pedestrian Impact Detection Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2016	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2016	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2016	ATS	Body	Radio/HVAC Control																																																										
A	2016	ATS	Body	Vehicle Performance Data Recorder																																																										
A	2016	ATS	Body	Trailer Interface Control Module																																																										
A	2016	ATS	Body	Radio																																																										
A	2016	ATS	Body	Amplifier																																																										
A	2016	ATS	Body	Rear Audio Control Module																																																										
A	2016	ATS	Body	Media Disc Player																																																										
A	2016	ATS	Body	Human Machine Interface Control Module																																																										
A	2016	ATS	Body	Navigation Control Module																																																										
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2016	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2016	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2016	ATS	Body	Seat Memory Control Module - Passenger																																																										
A	2016	ATS	Body	Seat Memory Control Module - Driver																																																										
A	2016	ATS	Body	Keyless Entry Control Module Coupe																																																										
A	2016	ATS	Body	Keyless Entry Control Module Sadan																																																										
A	2016	ATS	Body	Right Side Object Detection Control Module																																																										
A	2016	ATS	Body	Left Side Object Detection Control Module																																																										
A	2016	ATS	Body	Parking Assist Control Module																																																										
A	2016	ATS	Body	Frontview Camera Module																																																										
A	2016	ATS	Body	Steering Column Lock Control Module																																																										
A	2016	ATS	Body	Long Range Radar Sensor Module																																																										
A	2016	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2016	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2016	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2016	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
A	2016	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2016	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
A	2016	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
A	2016	CTS	Powertrain	(S) 3.6L LGX Engine Control Module																																																										
A	2016	CTS	Powertrain	(S) 3.6L LGX Transmission Control Module																																																										
A	2016	CTS	Powertrain	(6) 6.2L LT4 Engine Control Module																																																										
A	2016	CTS	Powertrain	(6) 6.2L LT4 Transmission Control Module																																																										
A	2016	CTS	Powertrain	Rear Differential Clutch Control Module																																																										
A	2016	CTS	Powertrain	Transfer Case Control Module																																																										
A	2016	CTS	Chassis	Electronic Brake Control Module																																																										
A	2016	CTS	Chassis	Parking Brake Control Module																																																										
A	2016	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2016	CTS	Chassis	Power Steering Control Module																																																										
A	2016	CTS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	CTS	Chassis	Suspension Control Module																																																										
A	2016	CTS	Body	Body Control Module Headlamp Type Halogen																																																										
A	2016	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2016	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	CTS	Body	Passenger Presence Module																																																										
A	2016	CTS	Body	Pedestrian Impact Detection Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2016	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2016	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2016	CTS	Body	Radio/HVAC Control																																																										
A	2016	CTS	Body	Vehicle Performance Data Recorder																																																										
A	2016	CTS	Body	Active Safety Control Module																																																										
A	2016	CTS	Body	Video Processing Control Module																																																										
A	2016	CTS	Body	Trailer Interface Control Module																																																										
A	2016	CTS	Body	Radio																																																										
A	2016	CTS	Body	Amplifier																																																										
A	2016	CTS	Body	Human Machine Interface Control Module																																																										
A	2016	CTS	Body	Navigation Control Module																																																										
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2016	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2016	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2016	CTS	Body	Seat Memory Control Module - Passenger																																																										
A	2016	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2016	CTS	Body	Keyless Entry Control Module																																																										
A	2016	CTS	Body	Right Side Object Detection Control Module																																																										
A	2016	CTS	Body	Left Side Object Detection Control Module																																																										
A	2016	CTS	Body	Parking Assist Control Module																																																										
A	2016	CTS	Body	Frontview Camera Module																																																										
A	2016	CTS	Body	Steering Column Lock Control Module																																																										
A	2016	CTS	Body	Long Range Radar Sensor Module																																																										
A	2016	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2016	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2016	CTS	Body	Rear Short Range Radar Sensor Module																																																										
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																										
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																										
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																										
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																										
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																										
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																										
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2004	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2004	(DM)CTS	Chassis	VES																																																										
D	2004	(DM)CTS	Body	Amplifier (Bose)																																																										
D	2004	(DM)CTS	Body	Amplifier (Delco)																																																										
D	2004	(DM)CTS	Body	Climate Control Panel																																																										
D	2004	(DM)CTS	Body	Dash Integration Module																																																										
D	2004	(DM)CTS	Body	Digital Radio Receiver																																																										
D	2004	(DM)CTS	Body	Driver Door Switch																																																										
D	2004	(DM)CTS	Body	Driver Door Module																																																										
D	2004	(DM)CTS	Body	Passenger Door Module																																																										
D	2004	(DM)CTS	Body	Left Rear Door Module																																																										
D	2004	(DM)CTS	Body	Right Rear Door Module																																																										
D	2004	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2004	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2004	(DM)CTS	Body	Instrument Panel Cluster																																																												
D	2004	(DM)CTS	Body	Memory Seat Module																																																												
D	2004	(DM)CTS	Body	Personalization																																																												
D	2004	(DM)CTS	Body	Rear Integration Module																																																												
D	2004	(DM)CTS	Body	Remote Function Actuation																																																												
D	2004	(DM)CTS	Body	Supplemental Inflatable Restraint	V																																																											
D	2004	(DM)CTS	Body	TV Antenna Module																																																												
D	2004	(DM)CTS	Body	Vehicle Theft Deterrent		V																																																										
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																												
D	2004	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2004	(DR)CTS	Chassis	VES																																																												
D	2004	(DR)CTS	Body	Amplifier (Bose)																																																												
D	2004	(DR)CTS	Body	Amplifier (Delco)																																																												
D	2004	(DR)CTS	Body	Climate Control Panel																																																												
D	2004	(DR)CTS	Body	Dash Integration Module																																																												
D	2004	(DR)CTS	Body	Digital Radio Receiver																																																												
D	2004	(DR)CTS	Body	Driver Door Switch																																																												
D	2004	(DR)CTS	Body	Driver Door Module																																																												
D	2004	(DR)CTS	Body	Passenger Door Module																																																												
D	2004	(DR)CTS	Body	Left Rear Door Module																																																												
D	2004	(DR)CTS	Body	Right Rear Door Module																																																												
D	2004	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2004	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2004	(DR)CTS	Body	Instrument Panel Cluster																																																												
D	2004	(DR)CTS	Body	Memory Seat Module																																																												
D	2004	(DR)CTS	Body	Personalization																																																												
D	2004	(DR)CTS	Body	Rear Integration Module																																																												
D	2004	(DR)CTS	Body	Remote Function Actuation																																																												
D	2004	(DR)CTS	Body	Supplemental Inflatable Restraint	V																																																											
D	2004	(DR)CTS	Body	TV Antenna Module																																																												
D	2004	(DR)CTS	Body	Vehicle Theft Deterrent		V																																																										
D	2004	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module			V	V	V																																																							
D	2004	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																												
D	2004	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																												
D	2004	(DN)CTS-V	Chassis	VES																																																												
D	2004	(DN)CTS-V	Body	Amplifier (Bose)																																																												
D	2004	(DN)CTS-V	Body	Amplifier (Delco)																																																												
D	2004	(DN)CTS-V	Body	Climate Control Panel																																																												
D	2004	(DN)CTS-V	Body	Dash Integration Module																																																												
D	2004	(DN)CTS-V	Body	Digital Radio Receiver																																																												
D	2004	(DN)CTS-V	Body	Driver Door Switch																																																												
D	2004	(DN)CTS-V	Body	Driver Door Module																																																												
D	2004	(DN)CTS-V	Body	Passenger Door Module																																																												
D	2004	(DN)CTS-V	Body	Left Rear Door Module																																																												
D	2004	(DN)CTS-V	Body	Right Rear Door Module																																																												
D	2004	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2004	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																										
D	2004	(DN)CTS-V	Body	Instrument Panel Cluster																																																										
D	2004	(DN)CTS-V	Body	Memory Seat Module																																																										
D	2004	(DN)CTS-V	Body	Personalization																																																										
D	2004	(DN)CTS-V	Body	Rear Integration Module																																																										
D	2004	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																										
D	2004	(DN)CTS-V	Body	Supplemental Inflatable Restraint	V																																																									
D	2004	(DN)CTS-V	Body	TV Antenna Module																																																										
D	2004	(DN)CTS-V	Body	Vehicle Theft Deterrent		V																																																								
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module					V	V																																																				
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V	V																																																				
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2005	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2005	(DM)CTS	Chassis	VES																																																										
D	2005	(DM)CTS	Body	Amplifier (Bose)																																																										
D	2005	(DM)CTS	Body	Amplifier (Delco)																																																										
D	2005	(DM)CTS	Body	Climate Control Panel																																																										
D	2005	(DM)CTS	Body	Dash Integration Module																																																										
D	2005	(DM)CTS	Body	Digital Radio Receiver																																																										
D	2005	(DM)CTS	Body	Driver Door Switch																																																										
D	2005	(DM)CTS	Body	Driver Door Module																																																										
D	2005	(DM)CTS	Body	Passenger Door Module																																																										
D	2005	(DM)CTS	Body	Left Rear Door Module																																																										
D	2005	(DM)CTS	Body	Right Rear Door Module																																																										
D	2005	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2005	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2005	(DM)CTS	Body	Instrument Panel Cluster																																																										
D	2005	(DM)CTS	Body	Memory Seat Module																																																										
D	2005	(DM)CTS	Body	Personalization																																																										
D	2005	(DM)CTS	Body	Rear Integration Module																																																										
D	2005	(DM)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DM)CTS	Body	Supplemental Inflatable Restraint	V																																																									
D	2005	(DM)CTS	Body	TV Antenna Module																																																										
D	2005	(DM)CTS	Body	Vehicle Theft Deterrent		V																																																								
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module					V	V																																																				
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V	V																																																				
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2005	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2005	(DP)CTS	Chassis	VES																																																										
D	2005	(DP)CTS	Body	Amplifier (Bose)																																																										
D	2005	(DP)CTS	Body	Amplifier (Delco)																																																										
D	2005	(DP)CTS	Body	Climate Control Panel																																																										
D	2005	(DP)CTS	Body	Dash Integration Module																																																										
D	2005	(DP)CTS	Body	Digital Radio Receiver																																																										
D	2005	(DP)CTS	Body	Driver Door Switch																																																										
D	2005	(DP)CTS	Body	Driver Door Module																																																										
D	2005	(DP)CTS	Body	Passenger Door Module																																																										
D	2005	(DP)CTS	Body	Left Rear Door Module																																																										
D	2005	(DP)CTS	Body	Right Rear Door Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2005	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2005	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2005	(DP)CTS	Body	Instrument Panel Cluster																																																											
D	2005	(DP)CTS	Body	Memory Seat Module																																																											
D	2005	(DP)CTS	Body	Personalization																																																											
D	2005	(DP)CTS	Body	Rear Integration Module																																																											
D	2005	(DP)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DP)CTS	Body	Supplemental Inflatable Restraint	V																																																										
D	2005	(DP)CTS	Body	TV Antenna Module																																																											
D	2005	(DP)CTS	Body	Vehicle Theft Deterrent		V																																																									
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module					V	V																																																					
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V	V																																																					
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2005	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2005	(DR)CTS	Chassis	VES																																																												
D	2005	(DR)CTS	Body	Amplifier (Bose)																																																												
D	2005	(DR)CTS	Body	Amplifier (Delco)																																																												
D	2005	(DR)CTS	Body	Climate Control Panel																																																												
D	2005	(DR)CTS	Body	Dash Integration Module																																																												
D	2005	(DR)CTS	Body	Digital Radio Receiver																																																												
D	2005	(DR)CTS	Body	Driver Door Switch																																																												
D	2005	(DR)CTS	Body	Driver Door Module																																																												
D	2005	(DR)CTS	Body	Passenger Door Module																																																												
D	2005	(DR)CTS	Body	Left Rear Door Module																																																												
D	2005	(DR)CTS	Body	Right Rear Door Module																																																												
D	2005	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2005	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2005	(DR)CTS	Body	Instrument Panel Cluster																																																												
D	2005	(DR)CTS	Body	Memory Seat Module																																																												
D	2005	(DR)CTS	Body	Personalization																																																												
D	2005	(DR)CTS	Body	Radio							V	V																																																				
D	2005	(DR)CTS	Body	Rear Integration Module																																																												
D	2005	(DR)CTS	Body	Remote Control Door Lock Receiver																																																												
D	2005	(DR)CTS	Body	Supplemental Inflatable Restraint	V																																																										
D	2005	(DR)CTS	Body	TV Antenna Module																																																												
D	2005	(DR)CTS	Body	Vehicle Theft Deterrent		V																																																									
D	2005	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module			V	V	V																																																						
D	2005	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																												
D	2005	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																												
D	2005	(DN)CTS-V	Chassis	VES																																																												
D	2005	(DN)CTS-V	Body	Amplifier (Bose)																																																												
D	2005	(DN)CTS-V	Body	Amplifier (Delco)																																																												
D	2005	(DN)CTS-V	Body	Climate Control Panel																																																												
D	2005	(DN)CTS-V	Body	Dash Integration Module																																																												
D	2005	(DN)CTS-V	Body	Digital Radio Receiver																																																												
D	2005	(DN)CTS-V	Body	Driver Door Switch																																																												
D	2005	(DN)CTS-V	Body	Driver Door Module																																																												
D	2005	(DN)CTS-V	Body	Passenger Door Module																																																												
D	2005	(DN)CTS-V	Body	Left Rear Door Module																																																												
D	2005	(DN)CTS-V	Body	Right Rear Door Module																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2005	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																								
D	2005	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																								
D	2005	(DN)CTS-V	Body	Instrument Panel Cluster																																																								
D	2005	(DN)CTS-V	Body	Memory Seat Module																																																								
D	2005	(DN)CTS-V	Body	Personalization																																																								
D	2005	(DN)CTS-V	Body	Radio							V	V																																																
D	2005	(DN)CTS-V	Body	Rear Integration Module																																																								
D	2005	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																								
D	2005	(DN)CTS-V	Body	Supplemental Inflatable Restraint	V																																																							
D	2005	(DN)CTS-V	Body	TV Antenna Module																																																								
D	2005	(DN)CTS-V	Body	Vehicle Theft Deterrent		V																																																						
D	2005	(DC)STS-V8	Powertrain	Engine Control Module					V	V			V	V																																														
D	2005	(DC)STS-V8	Powertrain	Transmission Control Module																																																								
D	2005	(DC)STS-V8	Chassis	Electronic Brake Control Module											V	V	V																																										
D	2005	(DC)STS-V8	Chassis	Electronic Suspension Control																																																								
D	2005	(DC)STS-V8	Body	Amplifier (Bose)																																																								
D	2005	(DC)STS-V8	Body	Digital Radio Receiver																																																								
D	2005	(DC)STS-V8	Body	Distance Sensing Cruise Control														V	V	V																																							
D	2005	(DC)STS-V8	Body	Driver Door Module																	V	V																																						
D	2005	(DC)STS-V8	Body	Driver Door Switch																																																								
D	2005	(DC)STS-V8	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																													
D	2005	(DC)STS-V8	Body	Headlamp Control Module																		V																																						
D	2005	(DC)STS-V8	Body	Head Up Display																		V																																						
D	2005	(DC)STS-V8	Body	HVAC Control Module																												V	V																											
D	2005	(DC)STS-V8	Body	Instrument Panel Cluster																		V																																						
D	2005	(DC)STS-V8	Body	Instrument Panel Module																													V	V	V	V	V	V	V	V																			
D	2005	(DC)STS-V8	Body	Left Rear Door Module																	V	V																																						
D	2005	(DC)STS-V8	Body	Passenger Door Module																	V	V																																						
D	2005	(DC)STS-V8	Body	Uplevel Radio								V																																																
D	2005	(DC)STS-V8	Body	Navigation Radio								V																													V	V																		
D	2005	(DC)STS-V8	Body	Rear Integration Module																																							V	V																
D	2005	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																									V	V	V	V	V	V	V									
D	2005	(DC)STS-V8	Body	Right Rear Door Module																	V	V																																						
D	2005	(DC)STS-V8	Body	Steering Column Lock Module																																																								
D	2005	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																								
D	2005	(DC)STS-V8	Body	TV Antenna Module																																																								
D	2005	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																															V	V	V	V					
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V	V																																																		
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2005	(DW)STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
D	2005	(DW)STS	Chassis	Electronic Brake Control Module											V	V	V																																										
D	2005	(DW)STS	Chassis	Electronic Suspension Control																																																								
D	2005	(DW)STS	Body	Amplifier (Bose)																																																								
D	2005	(DW)STS	Body	Digital Radio Receiver																																																								
D	2005	(DW)STS	Body	Distance Sensing Cruise Control														V	V	V																																							
D	2005	(DW)STS	Body	Driver Door Module																	V	V																																						
D	2005	(DW)STS	Body	Driver Door Switch																																																								
D	2005	(DW)STS	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																													
D	2005	(DW)STS	Body	Headlamp Control Module																		V																																						
D	2005	(DW)STS	Body	Head Up Display																		V																																						
D	2005	(DW)STS	Body	HVAC Control Module																												V	V																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2005	(DW)STS	Body	Instrument Panel Cluster																		V																																						
D	2005	(DW)STS	Body	Instrument Panel Module																													V	V	V	V	V	V	V	V																			
D	2005	(DW)STS	Body	Left Rear Door Module																	V	V																																						
D	2005	(DW)STS	Body	Passenger Door Module																	V	V																																						
D	2005	(DW)STS	Body	Uplevel Radio								V																																															
D	2005	(DW)STS	Body	Navigation Radio								V																													V	V																		
D	2005	(DW)STS	Body	Rear Integration Module																																							V	V																
D	2005	(DW)STS	Body	Remote Control Door Lock Receiver																																									V	V	V	V	V	V	V									
D	2005	(DW)STS	Body	Right Rear Door Module																	V	V																																						
D	2005	(DW)STS	Body	Steering Column Lock Module																																																								
D	2005	(DW)STS	Body	Supplemental Inflatable Restraint																																																								
D	2005	(DW)STS	Body	TV Antenna Module																																																								
D	2005	(DW)STS	Body	Vehicle Comm. Interface Module																																																V	V	V	V					
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module					V	V																																																		
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																								
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V	V																																																		
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2006	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																								
D	2006	(DM)CTS	Chassis	Tire Pressure Monitor																																																								
D	2006	(DM)CTS	Chassis	VES																																																								
D	2006	(DM)CTS	Body	Amplifier (Bose)																																																								
D	2006	(DM)CTS	Body	Amplifier (Delco)																																																								
D	2006	(DM)CTS	Body	Climate Control Panel																																																								
D	2006	(DM)CTS	Body	Dash Integration Module																																																								
D	2006	(DM)CTS	Body	Digital Radio Receiver																																																								
D	2006	(DM)CTS	Body	Driver Door Switch																																																								
D	2006	(DM)CTS	Body	Driver Door Module																																																								
D	2006	(DM)CTS	Body	Passenger Door Module																																																								
D	2006	(DM)CTS	Body	Left Rear Door Module																																																								
D	2006	(DM)CTS	Body	Right Rear Door Module																																																								
D	2006	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																								
D	2006	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																								
D	2006	(DM)CTS	Body	Instrument Panel Cluster																																																								
D	2006	(DM)CTS	Body	Memory Seat Module																																																								
D	2006	(DM)CTS	Body	Personalization																																																								
D	2006	(DM)CTS	Body	Radio							V	V																																																
D	2006	(DM)CTS	Body	Rear Integration Module																																																								
D	2006	(DM)CTS	Body	Remote Control Door Lock Receiver																																																								
D	2006	(DM)CTS	Body	Supplemental Inflatable Restraint	V																																																							
D	2006	(DM)CTS	Body	TV Antenna Module																																																								
D	2006	(DM)CTS	Body	Vehicle Theft Deterrent		V																																																						
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module					V	V																																																		
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																								
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V	V																																																		
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2006	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																								
D	2006	(DP)CTS	Chassis	Tire Pressure Monitor																																																								
D	2006	(DP)CTS	Chassis	VES																																																								
D	2006	(DP)CTS	Body	Amplifier (Bose)																																																								
D	2006	(DP)CTS	Body	Amplifier (Delco)																																																								
D	2006	(DP)CTS	Body	Climate Control Panel																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2006	(DP)CTS	Body	Dash Integration Module																																																												
D	2006	(DP)CTS	Body	Digital Radio Receiver																																																												
D	2006	(DP)CTS	Body	Driver Door Switch																																																												
D	2006	(DP)CTS	Body	Driver Door Module																																																												
D	2006	(DP)CTS	Body	Passenger Door Module																																																												
D	2006	(DP)CTS	Body	Left Rear Door Module																																																												
D	2006	(DP)CTS	Body	Right Rear Door Module																																																												
D	2006	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2006	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2006	(DP)CTS	Body	Instrument Panel Cluster																																																												
D	2006	(DP)CTS	Body	Memory Seat Module																																																												
D	2006	(DP)CTS	Body	Personalization																																																												
D	2006	(DP)CTS	Body	Radio							V	V																																																				
D	2006	(DP)CTS	Body	Rear Integration Module																																																												
D	2006	(DP)CTS	Body	Remote Control Door Lock Receiver																																																												
D	2006	(DP)CTS	Body	Supplemental Inflatable Restraint	V																																																											
D	2006	(DP)CTS	Body	TV Antenna Module																																																												
D	2006	(DP)CTS	Body	Vehicle Theft Deterrent		V																																																										
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module					V	V																																																						
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V	V																																																						
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2006	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2006	(DR)CTS	Chassis	Tire Pressure Monitor																																																												
D	2006	(DR)CTS	Chassis	VES																																																												
D	2006	(DR)CTS	Body	Amplifier (Bose)																																																												
D	2006	(DR)CTS	Body	Amplifier (Delco)																																																												
D	2006	(DR)CTS	Body	Climate Control Panel																																																												
D	2006	(DR)CTS	Body	Dash Integration Module																																																												
D	2006	(DR)CTS	Body	Digital Radio Receiver																																																												
D	2006	(DR)CTS	Body	Driver Door Switch																																																												
D	2006	(DR)CTS	Body	Driver Door Module																																																												
D	2006	(DR)CTS	Body	Passenger Door Module																																																												
D	2006	(DR)CTS	Body	Left Rear Door Module																																																												
D	2006	(DR)CTS	Body	Right Rear Door Module																																																												
D	2006	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2006	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2006	(DR)CTS	Body	Instrument Panel Cluster																																																												
D	2006	(DR)CTS	Body	Memory Seat Module																																																												
D	2006	(DR)CTS	Body	Personalization																																																												
D	2006	(DR)CTS	Body	Radio							V	V																																																				
D	2006	(DR)CTS	Body	Rear Integration Module																																																												
D	2006	(DR)CTS	Body	Remote Control Door Lock Receiver																																																												
D	2006	(DR)CTS	Body	Supplemental Inflatable Restraint	V																																																											
D	2006	(DR)CTS	Body	TV Antenna Module																																																												
D	2006	(DR)CTS	Body	Vehicle Theft Deterrent		V																																																										
D	2006	(DN)CTS-V	Powertrain	Engine Control Module					V																																																	V	V	V		
D	2006	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																												
D	2006	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																												
D	2006	(DN)CTS-V	Chassis	VES																																																												
D	2006	(DN)CTS-V	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2006	(DN)CTS-V	Body	Amplifier (Delco)																																																								
D	2006	(DN)CTS-V	Body	Climate Control Panel																																																								
D	2006	(DN)CTS-V	Body	Dash Integration Module																																																								
D	2006	(DN)CTS-V	Body	Digital Radio Receiver																																																								
D	2006	(DN)CTS-V	Body	Driver Door Switch																																																								
D	2006	(DN)CTS-V	Body	Driver Door Module																																																								
D	2006	(DN)CTS-V	Body	Passenger Door Module																																																								
D	2006	(DN)CTS-V	Body	Left Rear Door Module																																																								
D	2006	(DN)CTS-V	Body	Right Rear Door Module																																																								
D	2006	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																								
D	2006	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																								
D	2006	(DN)CTS-V	Body	Instrument Panel Cluster																																																								
D	2006	(DN)CTS-V	Body	Memory Seat Module																																																								
D	2006	(DN)CTS-V	Body	Personalization																																																								
D	2006	(DN)CTS-V	Body	Rear Integration Module																																																								
D	2006	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																								
D	2006	(DN)CTS-V	Body	Supplemental Inflatable Restraint	V																																																							
D	2006	(DN)CTS-V	Body	TV Antenna Module																																																								
D	2006	(DN)CTS-V	Body	Vehicle Theft Deterrent		V																																																						
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Engine Controls					V	V			V	V																																														
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
D	2006	(DC)STS-V8	Chassis	Electronic Brake Control Module											V	V	V																																											
D	2006	(DC)STS-V8	Chassis	Electronic Suspension Control																																																								
D	2006	(DC)STS-V8	Body	Amplifier (Bose)																																																								
D	2006	(DC)STS-V8	Body	Digital Radio Receiver																																																								
D	2006	(DC)STS-V8	Body	Distance Sensing Cruise Control														V	V	V																																								
D	2006	(DC)STS-V8	Body	Driver Door Module																	V	V																																						
D	2006	(DC)STS-V8	Body	Driver Door Switch																																																								
D	2006	(DC)STS-V8	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																													
D	2006	(DC)STS-V8	Body	Headlamp Control Module																		V																																						
D	2006	(DC)STS-V8	Body	Head Up Display																		V																																						
D	2006	(DC)STS-V8	Body	HVAC Control Module																												V	V																											
D	2006	(DC)STS-V8	Body	Instrument Panel Cluster																		V																																						
D	2006	(DC)STS-V8	Body	Instrument Panel Module																														V	V	V	V	V	V	V	V																			
D	2006	(DC)STS-V8	Body	Left Rear Door Module																	V	V																																						
D	2006	(DC)STS-V8	Body	Passenger Door Module																	V	V																																						
D	2006	(DC)STS-V8	Body	Uplevel Radio								V																																																
D	2006	(DC)STS-V8	Body	Navigation Radio								V																												V	V																			
D	2006	(DC)STS-V8	Body	Rear Integration Module																																						V	V																	
D	2006	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																								V	V	V	V	V	V	V										
D	2006	(DC)STS-V8	Body	Right Rear Door Module																	V	V																																						
D	2006	(DC)STS-V8	Body	Steering Column Lock Module																																																								
D	2006	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																								
D	2006	(DC)STS-V8	Body	TV Antenna Module																																																								
D	2006	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																															V	V	V	V						
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V	V																																																		
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2006	(DW)STS	Chassis	Electronic Brake Control Module											V	V	V																																											
D	2006	(DW)STS	Chassis	Electronic Suspension Control																																																								
D	2006	(DW)STS	Body	Amplifier (Bose)																																																								
D	2006	(DW)STS	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2006	(DW)STS	Body	Distance Sensing Cruise Control														V	V	V																																							
D	2006	(DW)STS	Body	Driver Door Module																	V	V																																					
D	2006	(DW)STS	Body	Driver Door Switch																																																							
D	2006	(DW)STS	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																													
D	2006	(DW)STS	Body	Headlamp Control Module																		V																																					
D	2006	(DW)STS	Body	Head Up Display																		V																																					
D	2006	(DW)STS	Body	HVAC Control Module																												V	V																											
D	2006	(DW)STS	Body	Instrument Panel Cluster																		V																																					
D	2006	(DW)STS	Body	Instrument Panel Module																														V	V	V	V	V	V	V	V																			
D	2006	(DW)STS	Body	Left Rear Door Module																	V	V																																					
D	2006	(DW)STS	Body	Passenger Door Module																	V	V																																					
D	2006	(DW)STS	Body	Uplevel Radio								V																																															
D	2006	(DW)STS	Body	Navigation Radio								V																														V	V																
D	2006	(DW)STS	Body	Rear Integration Module																																								V	V														
D	2006	(DW)STS	Body	Remote Control Door Lock Receiver																																										V	V	V	V	V	V	V							
D	2006	(DW)STS	Body	Right Rear Door Module																	V	V																																					
D	2006	(DW)STS	Body	Steering Column Lock Module																																																							
D	2006	(DW)STS	Body	Supplemental Inflatable Restraint																																																							
D	2006	(DW)STS	Body	TV Antenna Module																																																							
D	2006	(DW)STS	Body	Vehicle Comm. Interface Module																																																V	V	V	V				
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Engine Control Module					V																																																	V
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																							
D	2006	(DX)STS-V	Chassis	Electronic Brake Control Module											V	V	V																																									
D	2006	(DX)STS-V	Chassis	Electronic Suspension Control																																																							
D	2006	(DX)STS-V	Body	Amplifier (Bose)																																																							
D	2006	(DX)STS-V	Body	Digital Radio Receiver																																																							
D	2006	(DX)STS-V	Body	Distance Sensing Cruise Control														V	V	V																																							
D	2006	(DX)STS-V	Body	Driver Door Module																	V	V																																							
D	2006	(DX)STS-V	Body	Driver Door Switch																																																							
D	2006	(DX)STS-V	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																													
D	2006	(DX)STS-V	Body	Headlamp Control Module																		V																																					
D	2006	(DX)STS-V	Body	Head Up Display																		V																																					
D	2006	(DX)STS-V	Body	HVAC Control Module																												V	V																											
D	2006	(DX)STS-V	Body	Instrument Panel Cluster																		V																																					
D	2006	(DX)STS-V	Body	Instrument Panel Module																														V	V	V	V	V	V	V	V																			
D	2006	(DX)STS-V	Body	Left Rear Door Module																	V	V																																					
D	2006	(DX)STS-V	Body	Passenger Door Module																	V	V																																					
D	2006	(DX)STS-V	Body	Uplevel Radio								V																																															
D	2006	(DX)STS-V	Body	Navigation Radio								V																														V	V																
D	2006	(DX)STS-V	Body	Rear Integration Module																																								V	V														
D	2006	(DX)STS-V	Body	Remote Control Door Lock Receiver																																										V	V	V	V	V	V	V							
D	2006	(DX)STS-V	Body	Right Rear Door Module																	V	V																																					
D	2006	(DX)STS-V	Body	Steering Column Lock Module																																																							
D	2006	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																							
D	2006	(DX)STS-V	Body	TV Antenna Module																																																							
D	2006	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																V	V	V	V				
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto					V																																																	V
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual					V																																																	V
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																						
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto					V																																																	V
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual					V																																																	V

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2007	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2007	(DM)CTS	Chassis	VES																																																												
D	2007	(DM)CTS	Body	Amplifier (Bose)																																																												
D	2007	(DM)CTS	Body	Amplifier (Delco)																																																												
D	2007	(DM)CTS	Body	Climate Control Panel																																																												
D	2007	(DM)CTS	Body	Dash Integration Module																																																												
D	2007	(DM)CTS	Body	Digital Radio Receiver																																																												
D	2007	(DM)CTS	Body	Driver Door Switch																																																												
D	2007	(DM)CTS	Body	Driver Door Module																																																												
D	2007	(DM)CTS	Body	Passenger Door Module																																																												
D	2007	(DM)CTS	Body	Left Rear Door Module																																																												
D	2007	(DM)CTS	Body	Right Rear Door Module																																																												
D	2007	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2007	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2007	(DM)CTS	Body	Instrument Panel Cluster																																																												
D	2007	(DM)CTS	Body	Memory Seat Module																																																												
D	2007	(DM)CTS	Body	Personalization																																																												
D	2007	(DM)CTS	Body	Rear Integration Module																																																												
D	2007	(DM)CTS	Body	Remote Control Door Lock Receiver																																										V		V																
D	2007	(DM)CTS	Body	Supplemental Inflatable Restraint	V																																																											
D	2007	(DM)CTS	Body	Theft Deterrent Module		V																																																										
D	2007	(DM)CTS	Body	TV Antenna Module																																																												
D	2007	(DM)CTS	Body	Vehicle Comm. Interface Module																																																V	V										
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto					V																																																						V	
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual					V																																																						V	
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto					V																																																						V	
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual					V																																																						V	
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2007	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2007	(DP)CTS	Chassis	VES																																																												
D	2007	(DP)CTS	Body	Amplifier (Bose)																																																												
D	2007	(DP)CTS	Body	Amplifier (Delco)																																																												
D	2007	(DP)CTS	Body	Climate Control Panel																																																												
D	2007	(DP)CTS	Body	Dash Integration Module																																																												
D	2007	(DP)CTS	Body	Digital Radio Receiver																																																												
D	2007	(DP)CTS	Body	Driver Door Switch																																																												
D	2007	(DP)CTS	Body	Driver Door Module																																																												
D	2007	(DP)CTS	Body	Passenger Door Module																																																												
D	2007	(DP)CTS	Body	Left Rear Door Module																																																												
D	2007	(DP)CTS	Body	Right Rear Door Module																																																												
D	2007	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2007	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2007	(DP)CTS	Body	Instrument Panel Cluster																																																												
D	2007	(DP)CTS	Body	Memory Seat Module																																																												
D	2007	(DP)CTS	Body	Personalization																																																												
D	2007	(DP)CTS	Body	Rear Integration Module																																																												
D	2007	(DP)CTS	Body	Remote Control Door Lock Receiver																																										V		V																
D	2007	(DP)CTS	Body	Supplemental Inflatable Restraint	V																																																											
D	2007	(DP)CTS	Body	Theft Deterrent Module		V																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2007	(DP)CTS	Body	TV Antenna Module																																																										
D	2007	(DP)CTS	Body	Vehicle Comm. Interface Module																																															V	V							
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto					V																																																				V
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual					V																																																				V
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																									
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto					V																																																				V
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual					V																																																				V
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
D	2007	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																									
D	2007	(DR)CTS	Chassis	VES																																																									
D	2007	(DR)CTS	Body	Amplifier (Bose)																																																									
D	2007	(DR)CTS	Body	Amplifier (Delco)																																																									
D	2007	(DR)CTS	Body	Climate Control Panel																																																									
D	2007	(DR)CTS	Body	Dash Integration Module																																																									
D	2007	(DR)CTS	Body	Digital Radio Receiver																																																									
D	2007	(DR)CTS	Body	Driver Door Switch																																																									
D	2007	(DR)CTS	Body	Driver Door Module																																																									
D	2007	(DR)CTS	Body	Passenger Door Module																																																									
D	2007	(DR)CTS	Body	Left Rear Door Module																																																									
D	2007	(DR)CTS	Body	Right Rear Door Module																																																									
D	2007	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																									
D	2007	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																									
D	2007	(DR)CTS	Body	Instrument Panel Cluster																																																									
D	2007	(DR)CTS	Body	Memory Seat Module																																																									
D	2007	(DR)CTS	Body	Personalization																																																									
D	2007	(DR)CTS	Body	Rear Integration Module																																																									
D	2007	(DR)CTS	Body	Remote Control Door Lock Receiver																																								V		V															
D	2007	(DR)CTS	Body	Supplemental Inflatable Restraint	V																																																								
D	2007	(DR)CTS	Body	Theft Deterrent Module		V																																																							
D	2007	(DR)CTS	Body	TV Antenna Module																																																									
D	2007	(DR)CTS	Body	Vehicle Comm. Interface Module																																															V	V							
D	2007	(DN)CTS-V	Powertrain	(U)6.0L V8 LS2 Engine Control Module					V																																													V	V	V	
D	2007	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																									
D	2007	(DN)CTS-V	Chassis	VES																																																									
D	2007	(DN)CTS-V	Body	Amplifier (Bose)																																																									
D	2007	(DN)CTS-V	Body	Amplifier (Delco)																																																									
D	2007	(DN)CTS-V	Body	Climate Control Panel																																																									
D	2007	(DN)CTS-V	Body	Dash Integration Module																																																									
D	2007	(DN)CTS-V	Body	Digital Radio Receiver																																																									
D	2007	(DN)CTS-V	Body	Driver Door Switch																																																									
D	2007	(DN)CTS-V	Body	Driver Door Module																																																									
D	2007	(DN)CTS-V	Body	Passenger Door Module																																																									
D	2007	(DN)CTS-V	Body	Left Rear Door Module																																																									
D	2007	(DN)CTS-V	Body	Right Rear Door Module																																																									
D	2007	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																									
D	2007	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																									
D	2007	(DN)CTS-V	Body	Instrument Panel Cluster																																																									
D	2007	(DN)CTS-V	Body	Memory Seat Module																																																									
D	2007	(DN)CTS-V	Body	Personalization																																																									
D	2007	(DN)CTS-V	Body	Rear Integration Module																																																									
D	2007	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																								V		V															

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2007	(DN)CTS-V	Body	Supplemental Inflatable Restraint	V																																																							
D	2007	(DN)CTS-V	Body	Theft Deterrent Module		V																																																						
D	2007	(DN)CTS-V	Body	TV Antenna Module																																																								
D	2007	(DN)CTS-V	Body	Vehicle Comm. Interface Module																																															V	V						
D	2007	(DC)STS-V8	Powertrain	Engine Control Module					V																																													V			V
D	2007	(DC)STS-V8	Powertrain	Transmission Control Module																																																					
D	2007	(DC)STS-V8	Chassis	Electronic Brake Control Module											V	V	V																																								
D	2007	(DC)STS-V8	Chassis	Electronic Suspension Control																																																						
D	2007	(DC)STS-V8	Body	Amplifier (Bose)																																																					
D	2007	(DC)STS-V8	Body	Digital Radio Receiver																																																					
D	2007	(DC)STS-V8	Body	Distance Sensing Cruise Control														V	V	V																																					
D	2007	(DC)STS-V8	Body	Driver Door Module																	V	V																																				
D	2007	(DC)STS-V8	Body	Driver Door Switch																																																					
D	2007	(DC)STS-V8	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																											
D	2007	(DC)STS-V8	Body	Headlamp Control Module																																																					
D	2007	(DC)STS-V8	Body	Head Up Display																																																					
D	2007	(DC)STS-V8	Body	HVAC Control Module																												V																										
D	2007	(DC)STS-V8	Body	Instrument Panel Cluster																		V																																			
D	2007	(DC)STS-V8	Body	Instrument Panel Module																													V	V	V	V	V	V	V	V																	
D	2007	(DC)STS-V8	Body	Left Rear Door Module																	V	V																																			
D	2007	(DC)STS-V8	Body	Passenger Door Module																	V	V																																			
D	2007	(DC)STS-V8	Body	Uplevel Radio								V																																													
D	2007	(DC)STS-V8	Body	Navigation Radio																																				V	V																
D	2007	(DC)STS-V8	Body	Rear Integration Module																																						V	V														
D	2007	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																								V	V	V	V	V	V	V							
D	2007	(DC)STS-V8	Body	Right Rear Door Module																	V	V																																			
D	2007	(DC)STS-V8	Body	Steering Column Lock Module																																																					
D	2007	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																					
D	2007	(DC)STS-V8	Body	TV Antenna Module																																																					
D	2007	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																															V	V	V	V				
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																																V
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																					
D	2007	(DW)STS	Chassis	Electronic Brake Control Module											V	V	V																																								
D	2007	(DW)STS	Chassis	Electronic Suspension Control																																																					
D	2007	(DW)STS	Body	Amplifier (Bose)																																																					
D	2007	(DW)STS	Body	Digital Radio Receiver																																																					
D	2007	(DW)STS	Body	Distance Sensing Cruise Control														V	V	V																																					
D	2007	(DW)STS	Body	Driver Door Module																	V	V																																				
D	2007	(DW)STS	Body	Driver Door Switch																																																					
D	2007	(DW)STS	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																											
D	2007	(DW)STS	Body	Headlamp Control Module																																																					
D	2007	(DW)STS	Body	Head Up Display																																																					
D	2007	(DW)STS	Body	HVAC Control Module																												V																										
D	2007	(DW)STS	Body	Instrument Panel Cluster																		V																																			
D	2007	(DW)STS	Body	Instrument Panel Module																													V	V	V	V	V	V	V	V																	
D	2007	(DW)STS	Body	Left Rear Door Module																	V	V																																			
D	2007	(DW)STS	Body	Passenger Door Module																	V	V																																			
D	2007	(DW)STS	Body	Uplevel Radio								V																																												
D	2007	(DW)STS	Body	Navigation Radio																																				V	V																
D	2007	(DW)STS	Body	Rear Integration Module																																						V	V														
D	2007	(DW)STS	Body	Remote Control Door Lock Receiver																																								V	V	V	V	V	V	V							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2007	(DW)STS	Body	Right Rear Door Module																	V	V																																							
D	2007	(DW)STS	Body	Steering Column Lock Module																																																									
D	2007	(DW)STS	Body	Supplemental Inflatable Restraint																																																									
D	2007	(DW)STS	Body	TV Antenna Module																																																									
D	2007	(DW)STS	Body	Vehicle Comm. Interface Module																																															V	V	V	V					
D	2007	(DX)STS-V	Powertrain	Engine Control Module					V																																													V			V
D	2007	(DX)STS-V	Powertrain	Transmission Control Module																																																								
D	2007	(DX)STS-V	Chassis	Electronic Brake Control Module											V	V	V																																										
D	2007	(DX)STS-V	Chassis	Electronic Suspension Control																																																								
D	2007	(DX)STS-V	Body	Amplifier (Bose)																																																								
D	2007	(DX)STS-V	Body	Digital Radio Receiver																																																								
D	2007	(DX)STS-V	Body	Distance Sensing Cruise Control														V	V	V																																							
D	2007	(DX)STS-V	Body	Driver Door Module																	V	V																																							
D	2007	(DX)STS-V	Body	Driver Door Switch																																																								
D	2007	(DX)STS-V	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																														
D	2007	(DX)STS-V	Body	Headlamp Control Module																																																								
D	2007	(DX)STS-V	Body	Head Up Display																																																								
D	2007	(DX)STS-V	Body	HVAC Control Module																													V																												
D	2007	(DX)STS-V	Body	Instrument Panel Cluster																		V																																						
D	2007	(DX)STS-V	Body	Instrument Panel Module																														V	V	V	V	V	V	V	V																		
D	2007	(DX)STS-V	Body	Left Rear Door Module																	V	V																																							
D	2007	(DX)STS-V	Body	Passenger Door Module																	V	V																																							
D	2007	(DX)STS-V	Body	Uplevel Radio								V																																																
D	2007	(DX)STS-V	Body	Navigation Radio																																					V	V																		
D	2007	(DX)STS-V	Body	Rear Integration Module																																							V	V																
D	2007	(DX)STS-V	Body	Remote Control Door Lock Receiver																																									V	V	V	V	V	V	V									
D	2007	(DX)STS-V	Body	Right Rear Door Module																	V	V																																							
D	2007	(DX)STS-V	Body	Steering Column Lock Module																																																								
D	2007	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																								
D	2007	(DX)STS-V	Body	TV Antenna Module																																																								
D	2007	(DX)STS-V	Body	Vehicle Comm. Interface Module																																														V	V	V	V					
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module					V																																													V	V		V
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																							
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module					V																																													V	V		V
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																							
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																							
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																													V	V		V
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																							
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																							
D	2008	CTS	Chassis	Electronic Brake Control Module											V	V	V																																										
D	2008	CTS	Body	Body Control Module			V																													V			V																					
D	2008	CTS	Body	Body Control Module (aux.)																																																								
D	2008	CTS	Body	Driver Door Switch																																																								
D	2008	CTS	Body	Headlamp Control Module																																																								
D	2008	CTS	Body	HVAC Control Module																													V																												
D	2008	CTS	Body	Infotainment Faceplate Module																																																								
D	2008	CTS	Body	Instrument Panel Cluster																																																								
D	2008	CTS	Body	Memory Seat Module																					V	V																																		
D	2008	CTS	Body	Park Assist Module																																																								
D	2008	CTS	Body	Passenger Door Switch																																																								
D	2008	CTS	Body	Passenger Presence System																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2008	CTS	Body	Pedestrian Impact Detection Module																																																									
D	2008	CTS	Body	Radio																																																									
D	2008	CTS	Body	Supplemental Inflatable Restraint																			V																																						
D	2008	CTS	Body	TV Antenna Module																																																									
D	2008	CTS	Body	Vehicle Comm. Interface Module																																																V	V	V	V				
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module					V	V																																																		V
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																								
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V	V																																																		V
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V																																															V			V
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
D	2008	SLS	Chassis	Electronic Brake Control Module											V	V	V																																											
D	2008	SLS	Chassis	Electronic Suspension Control																																																									
D	2008	SLS	Body	Amplifier (Bose)																																																								
D	2008	SLS	Body	Driver Door Module																	V																																							
D	2008	SLS	Body	Driver Door Switch																																																								
D	2008	SLS	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																															
D	2008	SLS	Body	Headlamp Control Module																																																								
D	2008	SLS	Body	HVAC Control Module																													V																											
D	2008	SLS	Body	Instrument Panel Cluster																																																								
D	2008	SLS	Body	Instrument Panel Module																														V	V	V	V	V	V	V	V																			
D	2008	SLS	Body	Left Rear Door Module																	V	V																																						
D	2008	SLS	Body	Passenger Door Module																	V	V																																						
D	2008	SLS	Body	Radio																																																								
D	2008	SLS	Body	Rear HVAC/RSA																																																								
D	2008	SLS	Body	Rear Integration Module																																							V	V																
D	2008	SLS	Body	Remote Control Door Lock Receiver																																									V	V	V	V	V	V	V									
D	2008	SLS	Body	Right Rear Door Module																	V	V																																						
D	2008	SLS	Body	Supplemental Inflatable Restraint																																																								
D	2008	SLS	Body	TV Antenna Module																																																								
D	2008	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module					V																																															V			V
D	2008	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																								
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module					V																																														V			V
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																								
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V																																														V			V
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
D	2008	STS	Chassis	Electronic Brake Control Module With (RPO JL7)											V	V	V																																											
D	2008	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																								
D	2008	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																								
D	2008	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																								
D	2008	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)											V	V	V																																											
D	2008	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																								
D	2008	STS	Body	Amplifier (Bose)																																																								
D	2008	STS	Body	Digital Radio Receiver																																																								
D	2008	STS	Body	Distance Sensing Cruise Control														V	V	V																																								
D	2008	STS	Body	Driver Door Module																	V	V																																							
D	2008	STS	Body	Driver Door Switch																																																								
D	2008	STS	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																															
D	2008	STS	Body	Headlamp Control Module																																																								
D	2008	STS	Body	Head Up Display																																																								
D	2008	STS	Body	HVAC Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2008	STS	Body	Instrument Panel Cluster																																																										
D	2008	STS	Body	Instrument Panel Module																														V	V	V	V	V	V	V	V																					
D	2008	STS	Body	Left Rear Door Module																	V	V																																								
D	2008	STS	Body	Left Side Object Detection Module																																																										
D	2008	STS	Body	Passenger Door Module																	V	V																																								
D	2008	STS	Body	Uplevel Radio								V																																																		
D	2008	STS	Body	Navigation Radio																																					V	V																				
D	2008	STS	Body	Rear Integration Module																																							V	V																		
D	2008	STS	Body	Remote Control Door Lock Receiver																																									V	V	V	V	V	V	V											
D	2008	STS	Body	Right Rear Door Module																	V	V																																								
D	2008	STS	Body	Right Side Object Detection Module																																																										
D	2008	STS	Body	Steering Column Lock Module																																																										
D	2008	STS	Body	Supplemental Inflatable Restraint																																																										
D	2008	STS	Body	TV Antenna Module																																																										
D	2008	STS	Body	Vehicle Comm. Interface Module																																																V	V	V	V							
D	2008	STS	Body	Veh Direction Alert Alarm Warn Mod																																																										
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto					V																																															V					V
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual					V																																															V	V				
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module					V																																															V	V				V
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module					V																																															V	V				V
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																										
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																															V	V				V
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																										
D	2009	CTS	Chassis	Electronic Brake Control Module										V	V	V																																														
D	2009	CTS	Chassis	Electronic Suspension Control																																																										
D	2009	CTS	Chassis	Parking Brake Control Module																																																										
D	2009	CTS	Body	Body Control Module			V																													V			V																							
D	2009	CTS	Body	Body Control Module (aux.)																																																										
D	2009	CTS	Body	Driver Door Switch																																																										
D	2009	CTS	Body	Headlamp Control Module																																																										
D	2009	CTS	Body	HVAC Control Module																													V																													
D	2009	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																										
D	2009	CTS	Body	Instrument Panel Cluster (Other)																																																										
D	2009	CTS	Body	Memory Seat Module																					V	V																																				
D	2009	CTS	Body	Park Assist Module																																																										
D	2009	CTS	Body	Passenger Door Switch																																																										
D	2009	CTS	Body	Passenger Presence System																																																										
D	2009	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2009	CTS	Body	Radio																																																										
D	2009	CTS	Body	Supplemental Inflatable Restraint																			V																																							
D	2009	CTS	Body	TV Antenna Module																																																										
D	2009	CTS	Body	Vehicle Comm. Interface Module																																																V	V	V	V							
D	2009	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module					V	V																																																				V
D	2009	SLS	Powertrain	(T)2.8L V6 LP2 Transmission Control Module																																																										
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V	V																																																				V
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V																																																V			V
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
D	2009	SLS	Chassis	Electronic Brake Control Module											V	V	V																																										
D	2009	SLS	Chassis	Electronic Suspension Control																																																							
D	2009	SLS	Body	Amplifier (Bose)																																																							
D	2009	SLS	Body	Driver Door Module																	V																																							
D	2009	SLS	Body	Driver Door Switch																																																							
D	2009	SLS	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																														
D	2009	SLS	Body	Headlamp Control Module																																																							
D	2009	SLS	Body	HVAC Control Module																													V																											
D	2009	SLS	Body	Instrument Panel Cluster																																																							
D	2009	SLS	Body	Instrument Panel Module																														V	V	V	V	V	V	V	V																			
D	2009	SLS	Body	Left Rear Door Module																	V	V																																						
D	2009	SLS	Body	Passenger Door Module																	V	V																																						
D	2009	SLS	Body	Radio																																																							
D	2009	SLS	Body	Rear HVAC/RSA																																																							
D	2009	SLS	Body	Rear Integration Module																																							V	V																
D	2009	SLS	Body	Remote Control Door Lock Receiver																																									V	V	V	V	V	V	V									
D	2009	SLS	Body	Right Rear Door Module																	V	V																																						
D	2009	SLS	Body	Supplemental Inflatable Restraint																																																							
D	2009	SLS	Body	TV Antenna Module																																																							
D	2009	SLS	Body	Vehicle Comm. Interface Module																																						V										V		V						
D	2009	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module					V																																															V			V
D	2009	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																							
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module					V																																														V			V
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																							
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V																																														V			V
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																							
D	2009	STS	Chassis	Electronic Brake Control Module With (RPO JL7)											V	V	V																																										
D	2009	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																							
D	2009	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																							
D	2009	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																							
D	2009	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)											V	V	V																																										
D	2009	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																							
D	2009	STS	Body	Amplifier (Bose)																																																							
D	2009	STS	Body	Digital Radio Receiver																																																							
D	2009	STS	Body	Distance Sensing Cruise Control														V	V	V																																								
D	2009	STS	Body	Driver Door Module																	V	V																																							
D	2009	STS	Body	Driver Door Switch																																																							
D	2009	STS	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																														
D	2009	STS	Body	Headlamp Control Module																																																							
D	2009	STS	Body	Head Up Display																																																							
D	2009	STS	Body	HVAC Control Module																																																							
D	2009	STS	Body	Instrument Panel Cluster																																																							
D	2009	STS	Body	Instrument Panel Module																														V	V	V	V	V	V	V	V																			
D	2009	STS	Body	Left Rear Door Module																	V	V																																						
D	2009	STS	Body	Left Side Object Detection Module																																																							
D	2009	STS	Body	Passenger Door Module																	V	V																																						
D	2009	STS	Body	Uplevel Radio								V																																																
D	2009	STS	Body	Navigation Radio																																					V	V																		
D	2009	STS	Body	Rear Integration Module																																							V	V																

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2009	STS	Body	Remote Control Door Lock Receiver																																									V	V	V	V	V	V	V								
D	2009	STS	Body	Right Rear Door Module																	V	V																																				
D	2009	STS	Body	Right Side Object Detection Module																																																						
D	2009	STS	Body	Steering Column Lock Module																																																						
D	2009	STS	Body	Supplemental Inflatable Restraint																																																						
D	2009	STS	Body	TV Antenna Module																																																						
D	2009	STS	Body	Vehicle Comm. Interface Module																																															V	V	V	V				
D	2009	STS	Body	Veh Direction Alert Alarm Warn Mod																																																						
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto					V																																													V			V
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual					V																																													V	V		
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																						
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																						
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Auto					V																																																V
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Manual					V																																													V			
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transmission Control Module																																																						
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Fuel Pump Control Module																																																						
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transfer Case Control Module																																																						
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module Auto					V																																															V	V
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																						
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Fuel Pump Control Module																																																						
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																						
D	2010	CTS	Chassis	Electronic Brake Control Module											V	V	V																																									
D	2010	CTS	Chassis	Electronic Suspension Control																																																						
D	2010	CTS	Chassis	Parking Brake Control Module																																																						
D	2010	CTS	Body	Body Control Module			V																													V			V																				
D	2010	CTS	Body	Body Control Module (aux.)																																																						
D	2010	CTS	Body	Driver Door Switch																																																						
D	2010	CTS	Body	Headlamp Control Module																																																						
D	2010	CTS	Body	HVAC Control Module																												V																											
D	2010	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																						
D	2010	CTS	Body	Instrument Panel Cluster (Other)																																																						
D	2010	CTS	Body	Liftgate Module																																																						
D	2010	CTS	Body	Memory Seat Module																					V	V																																	
D	2010	CTS	Body	Park Assist Module																																																						
D	2010	CTS	Body	Passenger Door Switch																																																						
D	2010	CTS	Body	Passenger Presence System																																																						
D	2010	CTS	Body	Pedestrian Impact Detection Module																																																						
D	2010	CTS	Body	Radio																																																						
D	2010	CTS	Body	Supplemental Inflatable Restraint																																																						
D	2010	CTS	Body	TV Antenna Module																																																						
D	2010	CTS	Body	Vehicle Comm. Interface Module																																						V									V		V					
D	2010	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module					V																																															V	V
D	2010	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																						
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V																																													V			V
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																						
D	2010	STS	Chassis	Electronic Brake Control Module With (RPO JL7)											V	V	V																																									
D	2010	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																						
D	2010	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																						
D	2010	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																						
D	2010	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)											V	V	V																																									
D	2010	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2010	STS	Body	Amplifier (Bose)																																																								
D	2010	STS	Body	Digital Radio Receiver																																																								
D	2010	STS	Body	Distance Sensing Cruise Control														V	V	V																																								
D	2010	STS	Body	Driver Door Module																	V	V																																						
D	2010	STS	Body	Driver Door Switch																																																								
D	2010	STS	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																															
D	2010	STS	Body	Headlamp Control Module																																																								
D	2010	STS	Body	Head Up Display																																																								
D	2010	STS	Body	HVAC Control Module																																																								
D	2010	STS	Body	Instrument Panel Cluster																																																								
D	2010	STS	Body	Instrument Panel Module																													V	V	V	V	V	V	V	V																					
D	2010	STS	Body	Left Rear Door Module																	V	V																																						
D	2010	STS	Body	Left Side Object Detection Module																																																								
D	2010	STS	Body	Passenger Door Module																	V	V																																							
D	2010	STS	Body	Uplevel Radio								V																																																
D	2010	STS	Body	Navigation Radio																																					V	V																		
D	2010	STS	Body	Rear Integration Module																																							V	V																
D	2010	STS	Body	Remote Control Door Lock Receiver																																									V	V	V	V	V	V	V									
D	2010	STS	Body	Right Rear Door Module																	V	V																																						
D	2010	STS	Body	Right Side Object Detection Module																																																								
D	2010	STS	Body	Steering Column Lock Module																																																								
D	2010	STS	Body	Supplemental Inflatable Restraint																																																								
D	2010	STS	Body	TV Antenna Module																																																								
D	2010	STS	Body	Vehicle Comm. Interface Module																																						V										V		V						
D	2010	STS	Body	Veh Direction Alert Alarm Warn Mod																																																								
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto					V																																															V			V
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual					V																																														V	V		
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																								
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																								
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Auto					V																																																		V
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Manual					V																																															V			
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																								
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																								
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transfer Case Control Module																																																								
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Engine Control Module					V																																																		V
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																								
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Fuel Pump Control Module																																																								
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transfer Case Control Module																																																								
D	2011	CTS	Chassis	Electronic Brake Control Module											V	V	V																																											
D	2011	CTS	Chassis	Electronic Suspension Control																																																								
D	2011	CTS	Chassis	Parking Brake Control Module																																																								
D	2011	CTS	Body	Body Control Module (6.2L V8 LSA)			V																													V			V																					
D	2011	CTS	Body	Body Control Module (Other)			V																													V			V																					
D	2011	CTS	Body	Body Control Module (aux.)																																																								
D	2011	CTS	Body	Driver Door Switch																																																								
D	2011	CTS	Body	Headlamp Control Module																																																								
D	2011	CTS	Body	HVAC Control Module																													V																											
D	2011	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																								
D	2011	CTS	Body	Instrument Panel Cluster (Other)																																																								
D	2011	CTS	Body	Liftgate Module																																																								
D	2011	CTS	Body	Memory Seat Module																					V	V																																		

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2011	CTS	Body	Park Assist Module																																																								
D	2011	CTS	Body	Passenger Door Switch																																																								
D	2011	CTS	Body	Passenger Presence System																																																								
D	2011	CTS	Body	Pedestrian Impact Detection Module																																																								
D	2011	CTS	Body	Radio																																																								
D	2011	CTS	Body	Supplemental Inflatable Restraint																																																								
D	2011	CTS	Body	TV Antenna Module																																																								
D	2011	CTS	Body	Vehicle Comm. Interface Module																																																V		V						
D	2011	STS	Powertrain	(D)3.6L V6 LLT Engine Control Module					V																																																V	V
D	2011	STS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																								
D	2011	STS	Chassis	Electronic Brake Control Module											V	V	V																																											
D	2011	STS	Chassis	Electronic Suspension Control																																																								
D	2011	STS	Body	Amplifier (Bose)																																																								
D	2011	STS	Body	Digital Radio Receiver																																																								
D	2011	STS	Body	Distance Sensing Cruise Control														V	V	V																																								
D	2011	STS	Body	Driver Door Module																	V	V																																						
D	2011	STS	Body	Driver Door Switch																																																								
D	2011	STS	Body	Driver Position Module																			V	V	V	V	V	V	V	V	V																													
D	2011	STS	Body	Headlamp Control Module																																																								
D	2011	STS	Body	Head Up Display																																																								
D	2011	STS	Body	HVAC Control Module																																																								
D	2011	STS	Body	Instrument Panel Cluster																																																								
D	2011	STS	Body	Instrument Panel Module																													V	V	V	V	V	V	V	V																				
D	2011	STS	Body	Left Rear Door Module																	V	V																																						
D	2011	STS	Body	Left Side Object Detection Module																																																								
D	2011	STS	Body	Passenger Door Module																	V	V																																						
D	2011	STS	Body	Uplevel Radio								V																																																
D	2011	STS	Body	Navigation Radio																																					V	V																		
D	2011	STS	Body	Rear Integration Module																																							V	V																
D	2011	STS	Body	Remote Control Door Lock Receiver																																									V	V	V	V	V	V	V									
D	2011	STS	Body	Right Rear Door Module																	V	V																																						
D	2011	STS	Body	Right Side Object Detection Module																																																								
D	2011	STS	Body	Supplemental Inflatable Restraint																																																								
D	2011	STS	Body	TV Antenna Module																																																								
D	2011	STS	Body	Vehicle Comm. Interface Module																																						V										V		V						
D	2011	STS	Body	Veh Direction Alert Alarm Warn Mod																																																								
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto					V																																														V			V
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual					V																																														V	V		
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																								
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																								
D	2012	P Type Engine	Chassis	Electronic Brake Control Module											V	V	V																																											
D	2012	P Type Engine	Chassis	Electronic Suspension Control																																																								
D	2012	P Type Engine	Chassis	Parking Brake Control Module																																																								
D	2012	P Type Engine	Body	Body Control Module			V																													V			V																					
D	2012	P Type Engine	Body	Body Control Module (aux.)																																																								
D	2012	P Type Engine	Body	Driver Door Switch																																																								
D	2012	P Type Engine	Body	Headlamp Control Module																																																								
D	2012	P Type Engine	Body	HVAC Control Module																													V																											
D	2012	P Type Engine	Body	Instrument Panel Cluster																																																								
D	2012	P Type Engine	Body	Left Side Object Detection Module																																																								
D	2012	P Type Engine	Body	Liftgate Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2012	P Type Engine	Body	Memory Seat Module																					V	V																																		
D	2012	P Type Engine	Body	Park Assist Module																																																							
D	2012	P Type Engine	Body	Passenger Door Switch																																																							
D	2012	P Type Engine	Body	Passenger Presence System																																																							
D	2012	P Type Engine	Body	Pedestrian Impact Detection Module																																																							
D	2012	P Type Engine	Body	Radio																																																							
D	2012	P Type Engine	Body	Right Side Object Detection Module																																																							
D	2012	P Type Engine	Body	Supplemental Inflatable Restraint																																																							
D	2012	P Type Engine	Body	TV Antenna Module																																																							
D	2012	P Type Engine	Body	Vehicle Comm. Interface Module																																																V		V					
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto					V																																																		V
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual					V																																															V		
D	2012	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																						
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																						
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																						
D	2012	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module					V																																																	V
D	2012	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																						
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																						
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																						
D	2012	Other	Chassis	Electronic Brake Control Module											V	V	V																																										
D	2012	Other	Chassis	Electronic Suspension Control																																																							
D	2012	Other	Chassis	Parking Brake Control Module																																																						
D	2012	Other	Body	Body Control Module			V																													V			V																					
D	2012	Other	Body	Body Control Module (aux.)																																																							
D	2012	Other	Body	Driver Door Switch																																																							
D	2012	Other	Body	Headlamp Control Module																																																							
D	2012	Other	Body	HVAC Control Module																													V																											
D	2012	Other	Body	Instrument Panel Cluster																																																							
D	2012	Other	Body	Left Side Object Detection Module																																																							
D	2012	Other	Body	Liftgate Module																																																							
D	2012	Other	Body	Memory Seat Module																					V	V																																		
D	2012	Other	Body	Park Assist Module																																																							
D	2012	Other	Body	Passenger Door Switch																																																							
D	2012	Other	Body	Passenger Presence System																																																							
D	2012	Other	Body	Pedestrian Impact Detection Module																																																							
D	2012	Other	Body	Radio																																																							
D	2012	Other	Body	Right Side Object Detection Module																																																							
D	2012	Other	Body	Supplemental Inflatable Restraint																																																							
D	2012	Other	Body	TV Antenna Module																																																							
D	2012	Other	Body	Vehicle Comm. Interface Module																																																V		V					
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto					V																																														V			V
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual					V																																														V	V		
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																						
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																						
D	2013	P Type Engine	Chassis	Electronic Brake Control Module											V	V	V																																									
D	2013	P Type Engine	Chassis	Electronic Suspension Control																																																						
D	2013	P Type Engine	Chassis	Parking Brake Control Module																																																						
D	2013	P Type Engine	Body	Body Control Module			V																													V			V																				
D	2013	P Type Engine	Body	Body Control Module (aux.)																																																						
D	2013	P Type Engine	Body	Driver Door Switch																																																						
D	2013	P Type Engine	Body	Headlamp Control Module																																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2013	P Type Engine	Body	HVAC Control Module																													V																											
D	2013	P Type Engine	Body	Instrument Panel Cluster																																																								
D	2013	P Type Engine	Body	Left Side Object Detection Module																																																								
D	2013	P Type Engine	Body	Liftgate Module																																																								
D	2013	P Type Engine	Body	Memory Seat Module																					V	V																																			
D	2013	P Type Engine	Body	Park Assist Module																																																								
D	2013	P Type Engine	Body	Passenger Door Switch																																																								
D	2013	P Type Engine	Body	Passenger Presence System																																																								
D	2013	P Type Engine	Body	Pedestrian Impact Detection Module																																																								
D	2013	P Type Engine	Body	Radio																																																								
D	2013	P Type Engine	Body	Right Side Object Detection Module																																																								
D	2013	P Type Engine	Body	Supplemental Inflatable Restraint																																																								
D	2013	P Type Engine	Body	TV Antenna Module																																																								
D	2013	P Type Engine	Body	Vehicle Comm. Interface Module																																																V		V						
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto					V																																																			V
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual					V																																																V		
D	2013	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																								
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																								
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																								
D	2013	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module					V																																																			V
D	2013	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																								
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																								
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																								
D	2013	Other	Chassis	Electronic Brake Control Module											V	V	V																																											
D	2013	Other	Chassis	Electronic Suspension Control																																																								
D	2013	Other	Chassis	Parking Brake Control Module																																																								
D	2013	Other	Body	Body Control Module			V																													V			V																					
D	2013	Other	Body	Body Control Module (aux.)																																																								
D	2013	Other	Body	Driver Door Switch																																																								
D	2013	Other	Body	Headlamp Control Module																																																								
D	2013	Other	Body	HVAC Control Module																													V																											
D	2013	Other	Body	Instrument Panel Cluster																																																								
D	2013	Other	Body	Left Side Object Detection Module																																																								
D	2013	Other	Body	Liftgate Module																																																								
D	2013	Other	Body	Memory Seat Module																					V	V																																			
D	2013	Other	Body	Park Assist Module																																																								
D	2013	Other	Body	Passenger Door Switch																																																								
D	2013	Other	Body	Passenger Presence System																																																								
D	2013	Other	Body	Pedestrian Impact Detection Module																																																								
D	2013	Other	Body	Radio																																																								
D	2013	Other	Body	Right Side Object Detection Module																																																								
D	2013	Other	Body	Supplemental Inflatable Restraint																																																								
D	2013	Other	Body	TV Antenna Module																																																								
D	2013	Other	Body	Vehicle Comm. Interface Module																																																V		V						
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
D	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																								
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																								
D	2014	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																								
D	2014	CTS	Powertrain	Chassis Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2014	CTS	Powertrain	Transfer Case Control Module																																																										
D	2014	CTS	Chassis	Electronic Brake Control Module																																																											
D	2014	CTS	Chassis	Parking Brake Control Module																																																											
D	2014	CTS	Chassis	Suspension Control Module																																																											
D	2014	CTS	Body	Body Control Module Coupe																																																											
D	2014	CTS	Body	Body Control Module Station Wagon																																																											
D	2014	CTS	Body	Auxiliary Body Control Module																																																											
D	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	CTS	Body	Passenger Presence Module																																																											
D	2014	CTS	Body	Pedestrian Impact Detection Module																																																											
D	2014	CTS	Body	Instrument Cluster																																																											
D	2014	CTS	Body	Headlamp Control Module																																																											
D	2014	CTS	Body	Radio																																																											
D	2014	CTS	Body	Amplifier																																																											
D	2014	CTS	Body	Television Antenna Module																																																											
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	CTS	Body	HVAC Control Module																																																											
D	2014	CTS	Body	Driver Door Switch Panel Control Module																																																											
D	2014	CTS	Body	Passenger Door Switch Panel Control Module																																																											
D	2014	CTS	Body	Liftgate Control Module																																																											
D	2014	CTS	Body	Seat Memory Control Module																																																											
D	2014	CTS	Body	Right Side Object Detection Control Module																																																											
D	2014	CTS	Body	Left Side Object Detection Control Module																																																											
D	2014	CTS	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																									V																	
D	2014	CTS	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
D	2014	CTS	Body	Parking Assist Control Module																																																											
D	2014	CTS	Body	Theft Deterrent Module		V																																																									
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
D	2015	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																											
D	2015	CTS	Powertrain	Chassis Control Module																																																											
D	2015	CTS	Powertrain	Transfer Case Control Module																																																											
D	2015	CTS	Chassis	Electronic Brake Control Module																																																											
D	2015	CTS	Chassis	Parking Brake Control Module																																																											
D	2015	CTS	Chassis	Suspension Control Module																																																											
D	2015	CTS	Body	Body Control Module Coupe																																																											
D	2015	CTS	Body	Body Control Module Station Wagon																																																											
D	2015	CTS	Body	Auxiliary Body Control Module																																																											
D	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	CTS	Body	Passenger Presence Module																																																											
D	2015	CTS	Body	Pedestrian Impact Detection Module																																																											
D	2015	CTS	Body	Instrument Cluster																																																											
D	2015	CTS	Body	Headlamp Control Module																																																											
D	2015	CTS	Body	Radio																																																											
D	2015	CTS	Body	Amplifier																																																											
D	2015	CTS	Body	Television Antenna Module																																																											
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2015	CTS	Body	HVAC Control Module																																																											
D	2015	CTS	Body	Driver Door Switch Panel Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2015	CTS	Body	Passenger Door Switch Panel Control Module																																																												
D	2015	CTS	Body	Liftgate Control Module																																																												
D	2015	CTS	Body	Seat Memory Control Module																																																												
D	2015	CTS	Body	Right Side Object Detection Control Module																																																												
D	2015	CTS	Body	Left Side Object Detection Control Module																																																												
D	2015	CTS	Body	Remote Control Door Lock Receiver																																									V																		
D	2015	CTS	Body	Parking Assist Control Module																																																											
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module			V		V																																																						
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module					V																																																						
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module			V		V																																																						
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module					V																																																						
K	2004	(KD)Deville	Body	Amplifier (Delco)																																																												
K	2004	(KD)Deville	Body	CD Changer																																																												
K	2004	(KD)Deville	Body	Dash Integration Module																																																												
K	2004	(KD)Deville	Body	Digital Radio Receiver																																																												
K	2004	(KD)Deville	Body	Driver Door Switch																																																												
K	2004	(KD)Deville	Body	Driver Door Module																																																												
K	2004	(KD)Deville	Body	Passenger Door Module																																																												
K	2004	(KD)Deville	Body	Left Rear Door Module																																																												
K	2004	(KD)Deville	Body	Right Rear Door Module																																																												
K	2004	(KD)Deville	Body	Instrument Panel Cluster																																																												
K	2004	(KD)Deville	Body	Instrument Panel Module																																																												
K	2004	(KD)Deville	Body	Memory Seat Module																		V																																										
K	2004	(KD)Deville	Body	Navigation Radio							V																																																					
K	2004	(KD)Deville	Body	Radio							V	V																																																				
K	2004	(KD)Deville	Body	Rear Climate Control Panel																																																												
K	2004	(KD)Deville	Body	Rear Integration Module																																							V																					
K	2004	(KD)Deville	Body	Remote Function Actuation																																									V																	
K	2004	(KD)Deville	Body	Supplemental Inflatable Restraint	V																																																										
K	2004	(KD)Deville	Body	Tilt Telescope Module																																																												
K	2004	(KD)Deville	Body	Vehicle Theft Deterrent																																																											
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module			V		V																																																						
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module					V																																																						
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module			V		V																																																						
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module					V																																																						
K	2004	(KE)DHS	Body	Amplifier (Bose)																																																												
K	2004	(KE)DHS	Body	CD Changer																																																												
K	2004	(KE)DHS	Body	Dash Integration Module																																																												
K	2004	(KE)DHS	Body	Digital Radio Receiver																																																												
K	2004	(KE)DHS	Body	Driver Door Switch																																																												
K	2004	(KE)DHS	Body	Driver Door Module																																																												
K	2004	(KE)DHS	Body	Passenger Door Module																																																												
K	2004	(KE)DHS	Body	Left Rear Door Module																																																												
K	2004	(KE)DHS	Body	Right Rear Door Module																																																												
K	2004	(KE)DHS	Body	Instrument Panel Cluster																																																												
K	2004	(KE)DHS	Body	Instrument Panel Module																																																												
K	2004	(KE)DHS	Body	Memory Seat Module																																																												
K	2004	(KE)DHS	Body	Navigation Radio							V																																																					
K	2004	(KE)DHS	Body	Radio							V	V																																																				
K	2004	(KE)DHS	Body	Rear Climate Control Panel																																																												
K	2004	(KE)DHS	Body	Rear Integration Module																																							V																					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2004	(KE)DHS	Body	Remote Function Actuation																																									V																
K	2004	(KE)DHS	Body	Supplemental Inflatable Restraint	V																																																								
K	2004	(KE)DHS	Body	Tilt Telescope Module																																																										
K	2004	(KE)DHS	Body	Vehicle Theft Deterrent																																																										
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module			V		V																																																					
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module					V																																																					
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module			V		V																																																					
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module					V																																																					
K	2004	(KF)DTS	Body	Amplifier (Bose)																																																										
K	2004	(KF)DTS	Body	CD Changer																																																										
K	2004	(KF)DTS	Body	Dash Integration Module																																																										
K	2004	(KF)DTS	Body	Digital Radio Receiver																																																										
K	2004	(KF)DTS	Body	Driver Door Switch																																																										
K	2004	(KF)DTS	Body	Driver Door Module																																																										
K	2004	(KF)DTS	Body	Passenger Door Module																																																										
K	2004	(KF)DTS	Body	Left Rear Door Module																																																										
K	2004	(KF)DTS	Body	Right Rear Door Module																																																										
K	2004	(KF)DTS	Body	Instrument Panel Cluster																																																										
K	2004	(KF)DTS	Body	Instrument Panel Module																																																										
K	2004	(KF)DTS	Body	Memory Seat Module																																																										
K	2004	(KF)DTS	Body	Navigation Radio							V																																																			
K	2004	(KF)DTS	Body	Radio							V	V																																																		
K	2004	(KF)DTS	Body	Rear Climate Control Panel																																																										
K	2004	(KF)DTS	Body	Rear Integration Module																																							V																				
K	2004	(KF)DTS	Body	Remote Function Actuation																																									V																
K	2004	(KF)DTS	Body	Supplemental Inflatable Restraint	V																																																								
K	2004	(KF)DTS	Body	Tilt Telescope Module																																																										
K	2004	(KF)DTS	Body	Vehicle Theft Deterrent																																																										
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Engine Control Module			V		V																																																				
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Transmission Control Module					V																																																					
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module			V		V																																																					
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module					V																																																					
K	2004	(KS)Seville SLS	Body	Amplifier (Bose)																																																										
K	2004	(KS)Seville SLS	Body	Amplifier (Delco)																																																										
K	2004	(KS)Seville SLS	Body	CD Changer																																																										
K	2004	(KS)Seville SLS	Body	Dash Integration Module																																																										
K	2004	(KS)Seville SLS	Body	Digital Radio Receiver																																																										
K	2004	(KS)Seville SLS	Body	Driver Door Module																																																										
K	2004	(KS)Seville SLS	Body	Instrument Panel Cluster																																																										
K	2004	(KS)Seville SLS	Body	Instrument Panel Module																																																										
K	2004	(KS)Seville SLS	Body	Memory Seat Module																																																										
K	2004	(KS)Seville SLS	Body	Navigation Radio							V																																																			
K	2004	(KS)Seville SLS	Body	Radio							V	V																																																		
K	2004	(KS)Seville SLS	Body	Rear Integration Module																																							V																				
K	2004	(KS)Seville SLS	Body	Remote Function Actuation																																									V																
K	2004	(KS)Seville SLS	Body	Supplemental Inflatable Restraint																	V																																								
K	2004	(KS)Seville SLS	Body	Tilt Telescope Module																																																										
K	2004	(KS)Seville SLS	Body	Vehicle Theft Deterrent																																																										
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Engine Control Module			V		V																																																				
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Transmission Control Module					V																																																					
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module			V		V																																																					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module					V																																																				
K	2004	(KY)Seville STS	Body	Amplifier (Bose)																																																										
K	2004	(KY)Seville STS	Body	Amplifier (Delco)																																																										
K	2004	(KY)Seville STS	Body	CD Changer																																																										
K	2004	(KY)Seville STS	Body	Dash Integration Module																																																										
K	2004	(KY)Seville STS	Body	Digital Radio Receiver																																																										
K	2004	(KY)Seville STS	Body	Driver Door Module																																																										
K	2004	(KY)Seville STS	Body	Instrument Panel Cluster																																																										
K	2004	(KY)Seville STS	Body	Instrument Panel Module																																																										
K	2004	(KY)Seville STS	Body	Memory Seat Module																																																										
K	2004	(KY)Seville STS	Body	Navigation Radio							V																																																		
K	2004	(KY)Seville STS	Body	Radio							V	V																																																		
K	2004	(KY)Seville STS	Body	Rear Integration Module																																							V																			
K	2004	(KY)Seville STS	Body	Remote Function Actuation																																								V																	
K	2004	(KY)Seville STS	Body	Supplemental Inflatable Restraint																	V																																								
K	2004	(KY)Seville STS	Body	Tilt Telescope Module																																																										
K	2004	(KY)Seville STS	Body	Vehicle Theft Deterrent																																																										
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module			V		V																																																					
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module					V																																																					
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module			V		V																																																					
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module					V																																																					
K	2005	(KD)Deville	Body	Amplifier (Delco)																																																										
K	2005	(KD)Deville	Body	CD Changer																																																										
K	2005	(KD)Deville	Body	Dash Integration Module																																																										
K	2005	(KD)Deville	Body	Digital Radio Receiver																																																										
K	2005	(KD)Deville	Body	Driver Door Switch																																																										
K	2005	(KD)Deville	Body	Driver Door Module																																																										
K	2005	(KD)Deville	Body	Passenger Door Module																																																										
K	2005	(KD)Deville	Body	Left Rear Door Module																																																										
K	2005	(KD)Deville	Body	Right Rear Door Module																																																										
K	2005	(KD)Deville	Body	Instrument Panel Cluster																																																										
K	2005	(KD)Deville	Body	Instrument Panel Module																																																										
K	2005	(KD)Deville	Body	Memory Seat Module																																																										
K	2005	(KD)Deville	Body	Navigation Radio							V																																																		
K	2005	(KD)Deville	Body	Radio							V	V																																																		
K	2005	(KD)Deville	Body	Rear Climate Control Panel																																																										
K	2005	(KD)Deville	Body	Rear Integration Module																																							V																			
K	2005	(KD)Deville	Body	Remote Function Actuation																																								V																	
K	2005	(KD)Deville	Body	Supplemental Inflatable Restraint	V																																																									
K	2005	(KD)Deville	Body	Tilt Telescope Module																																																										
K	2005	(KD)Deville	Body	Vehicle Theft Deterrent																																																										
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module			V		V																																																					
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module					V																																																					
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module			V		V																																																					
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module					V																																																					
K	2005	(KE)DHS	Body	Amplifier (Bose)																																																										
K	2005	(KE)DHS	Body	CD Changer																																																										
K	2005	(KE)DHS	Body	Dash Integration Module																																																										
K	2005	(KE)DHS	Body	Digital Radio Receiver																																																										
K	2005	(KE)DHS	Body	Driver Door Switch																																																										
K	2005	(KE)DHS	Body	Driver Door Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2005	(KE)DHS	Body	Passenger Door Module																																																									
K	2005	(KE)DHS	Body	Left Rear Door Module																																																									
K	2005	(KE)DHS	Body	Right Rear Door Module																																																									
K	2005	(KE)DHS	Body	Instrument Panel Cluster																																																									
K	2005	(KE)DHS	Body	Instrument Panel Module																																																									
K	2005	(KE)DHS	Body	Memory Seat Module																																																									
K	2005	(KE)DHS	Body	Navigation Radio							V																																																		
K	2005	(KE)DHS	Body	Radio							V	V																																																	
K	2005	(KE)DHS	Body	Rear Climate Control Panel																																																									
K	2005	(KE)DHS	Body	Rear Integration Module																																							V																		
K	2005	(KE)DHS	Body	Remote Function Actuation																																								V																	
K	2005	(KE)DHS	Body	Supplemental Inflatable Restraint	V																																																								
K	2005	(KE)DHS	Body	Tilt Telescope Module																																																									
K	2005	(KE)DHS	Body	Vehicle Theft Deterrent																																																									
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module			V		V																																																				
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module					V																																																				
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module			V		V																																																				
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module					V																																																				
K	2005	(KF)DTS	Body	Amplifier (Bose)																																																									
K	2005	(KF)DTS	Body	CD Changer																																																									
K	2005	(KF)DTS	Body	Dash Integration Module																																																									
K	2005	(KF)DTS	Body	Digital Radio Receiver																																																									
K	2005	(KF)DTS	Body	Driver Door Switch																																																									
K	2005	(KF)DTS	Body	Driver Door Module																																																									
K	2005	(KF)DTS	Body	Passenger Door Module																																																									
K	2005	(KF)DTS	Body	Left Rear Door Module																																																									
K	2005	(KF)DTS	Body	Right Rear Door Module																																																									
K	2005	(KF)DTS	Body	Instrument Panel Cluster																																																									
K	2005	(KF)DTS	Body	Instrument Panel Module																																																									
K	2005	(KF)DTS	Body	Memory Seat Module																																																									
K	2005	(KF)DTS	Body	Navigation Radio							V																																																		
K	2005	(KF)DTS	Body	Radio							V	V																																																	
K	2005	(KF)DTS	Body	Rear Climate Control Panel																																																									
K	2005	(KF)DTS	Body	Rear Integration Module																																							V																		
K	2005	(KF)DTS	Body	Remote Function Actuation																																								V																	
K	2005	(KF)DTS	Body	Supplemental Inflatable Restraint	V																																																								
K	2005	(KF)DTS	Body	Tilt Telescope Module																																																									
K	2005	(KF)DTS	Body	Vehicle Theft Deterrent																																																									
K	2006	ALL	Powertrain	Engine Control Module					V																																																			V	V
K	2006	ALL	Powertrain	Automatic Transaxle																																																									
K	2006	ALL	Chassis	Antilock Brake System										V	V	V																																													
K	2006	ALL	Body	Amplifier (Bose)																																																									
K	2006	ALL	Body	Aux. HVAC Control Module																													V																												
K	2006	ALL	Body	Body Control Module			V																													V																								
K	2006	ALL	Body	Digital Radio Receiver																																																									
K	2006	ALL	Body	Distance Sensing Cruise Control														V		V																																									
K	2006	ALL	Body	Driver Door Switch																																																									
K	2006	ALL	Body	Driver Position Module																					V	V																																			
K	2006	ALL	Body	HVAC Control Module																													V																												
K	2006	ALL	Body	Instrument Panel Cluster																																																									
K	2006	ALL	Body	Park Assist Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2006	ALL	Body	Passenger Door Switch																																																										
K	2006	ALL	Body	Passenger Presence System																																																										
K	2006	ALL	Body	Radio																																																										
K	2006	ALL	Body	Rear Heated Seat Module																																																										
K	2006	ALL	Body	Remote Control Door Lock Receiver																																																										
K	2006	ALL	Body	Supplemental Inflatable Restraint																			V																																							
K	2006	ALL	Body	Theft Deterrent Module		V																																																								
K	2006	ALL	Body	TV Antenna Module																																																										
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																V	V	V	V							
K	2007	ALL	Powertrain	Engine Control Module					V																																															V			V			
K	2007	ALL	Powertrain	Transmission Control Module																																																										
K	2007	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
K	2007	ALL	Body	Amplifier (Bose)																																																										
K	2007	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																													V																													
K	2007	ALL	Body	Body Control Module			V																													V			V																							
K	2007	ALL	Body	Digital Radio Receiver																																																										
K	2007	ALL	Body	Distance Sensing Cruise Control														V		V																																										
K	2007	ALL	Body	Driver Door Switch																																																										
K	2007	ALL	Body	Driver Position Module																					V	V																																				
K	2007	ALL	Body	CJ2 Dual Zone HVAC Auto																													V																													
K	2007	ALL	Body	CJ4 Tri Zone HVAC Auto																													V																													
K	2007	ALL	Body	Inside Rear View Mirror Module																																																										
K	2007	ALL	Body	Instrument Panel Cluster																																																										
K	2007	ALL	Body	Park Assist Module																																																										
K	2007	ALL	Body	Passenger Door Switch																																																										
K	2007	ALL	Body	Passenger Presence System																																																										
K	2007	ALL	Body	Radio																																																										
K	2007	ALL	Body	Rear Heated Seat Module																																																										
K	2007	ALL	Body	Supplemental Inflatable Restraint																			V																																							
K	2007	ALL	Body	Theft Deterrent Module		V																																																								
K	2007	ALL	Body	TV Antenna Module																																																										
K	2007	ALL	Body	Vehicle Comm. Interface Module																																																V	V	V	V							
K	2008	ALL	Powertrain	Engine Control Module					V																																															V			V			
K	2008	ALL	Powertrain	Transmission Control Module																																																										
K	2008	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
K	2008	ALL	Body	Amplifier (Bose)																																																										
K	2008	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																										
K	2008	ALL	Body	Body Control Module			V																													V			V																							
K	2008	ALL	Body	Digital Radio Receiver																																																										
K	2008	ALL	Body	Distance Sensing Cruise Control														V		V																																										
K	2008	ALL	Body	Driver Door Switch																																																										
K	2008	ALL	Body	Driver Position Module																					V	V																																				
K	2008	ALL	Body	CJ2 Dual Zone HVAC Auto																																																										
K	2008	ALL	Body	CJ4 Tri Zone HVAC Auto																																																										
K	2008	ALL	Body	Inside Rear View Mirror Module																																																										
K	2008	ALL	Body	Instrument Panel Cluster																																																										
K	2008	ALL	Body	Left Side Object Detection Module																																																										
K	2008	ALL	Body	Park Assist Module																																																										
K	2008	ALL	Body	Passenger Door Switch																																																										
K	2008	ALL	Body	Passenger Presence System																																																										
K	2008	ALL	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2008	ALL	Body	Rear Heated Seat Module																																																								
K	2008	ALL	Body	Right Side Object Detection Module																																																								
K	2008	ALL	Body	Supplemental Inflatable Restraint																			V																																					
K	2008	ALL	Body	Theft Deterrent Module		V																																																						
K	2008	ALL	Body	TV Antenna Module																																																								
K	2008	ALL	Body	Vehicle Comm. Interface Module																																															V	V	V	V				
K	2008	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																							
K	2009	ALL	Powertrain	Engine Control Module					V																																													V		V	V
K	2009	ALL	Powertrain	Transmission Control Module																																																							
K	2009	ALL	Chassis	Electronic Brake Control Module											V	V	V																																										
K	2009	ALL	Body	Amplifier (Bose)																																																							
K	2009	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																							
K	2009	ALL	Body	Body Control Module			V																													V			V																					
K	2009	ALL	Body	Digital Radio Receiver																																																							
K	2009	ALL	Body	Distance Sensing Cruise Control														V		V																																							
K	2009	ALL	Body	Driver Door Switch																																																							
K	2009	ALL	Body	Driver Position Module																					V	V																																		
K	2009	ALL	Body	CJ2 Dual Zone HVAC Auto																																																							
K	2009	ALL	Body	CJ4 Tri Zone HVAC Auto																																																							
K	2009	ALL	Body	Inside Rear View Mirror Module																																																							
K	2009	ALL	Body	Instrument Panel Cluster																																																							
K	2009	ALL	Body	Left Side Object Detection Module																																																							
K	2009	ALL	Body	Park Assist Module																																																							
K	2009	ALL	Body	Passenger Door Switch																																																							
K	2009	ALL	Body	Passenger Presence System																																																							
K	2009	ALL	Body	Radio																																																							
K	2009	ALL	Body	Rear Heated Seat Module																																																							
K	2009	ALL	Body	Right Side Object Detection Module																																																							
K	2009	ALL	Body	Supplemental Inflatable Restraint																			V																																					
K	2009	ALL	Body	Theft Deterrent Module		V																																																						
K	2009	ALL	Body	TV Antenna Module																																																							
K	2009	ALL	Body	Vehicle Comm. Interface Module																																															V		V					
K	2009	ALL	Body	Vehicle Comm. Interface Module																																															V		V					
K	2009	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																							
K	2010	ALL	Powertrain	Engine Control Module					V																																													V		V	V
K	2010	ALL	Powertrain	Transmission Control Module																																																							
K	2010	ALL	Chassis	Electronic Brake Control Module											V	V	V																																										
K	2010	ALL	Body	Amplifier (Bose)																																																							
K	2010	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																							
K	2010	ALL	Body	Body Control Module			V																													V			V																					
K	2010	ALL	Body	Digital Radio Receiver																																																							
K	2010	ALL	Body	Distance Sensing Cruise Control														V		V																																							
K	2010	ALL	Body	Driver Door Switch																																																							
K	2010	ALL	Body	Driver Position Module																					V	V																																		
K	2010	ALL	Body	CJ2 Dual Zone HVAC Auto																																																							
K	2010	ALL	Body	CJ4 Tri Zone HVAC Auto																																																							
K	2010	ALL	Body	Inside Rear View Mirror Module																																																							
K	2010	ALL	Body	Instrument Panel Cluster																																																							
K	2010	ALL	Body	Left Side Object Detection Module																																																							
K	2010	ALL	Body	Park Assist Module																																																							
K	2010	ALL	Body	Passenger Door Switch																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2010	ALL	Body	Passenger Presence System																																																								
K	2010	ALL	Body	Radio																																																								
K	2010	ALL	Body	Rear Heated Seat Module																																																								
K	2010	ALL	Body	Right Side Object Detection Module																																																								
K	2010	ALL	Body	Supplemental Inflatable Restraint																			V																																						
K	2010	ALL	Body	Theft Deterrent Module		V																																																							
K	2010	ALL	Body	TV Antenna Module																																																								
K	2010	ALL	Body	Vehicle Comm. Interface Module																																															V		V							
K	2010	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																								
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Engine Control Module					V																																														V		V	V
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Transmission Control Module																																																								
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Engine Control Module					V																																														V		V	V
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Transmission Control Module																																																								
K	2011	ALL	Chassis	Electronic Brake Control Module											V	V	V																																											
K	2011	ALL	Body	Amplifier (Bose)																																																								
K	2011	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																								
K	2011	ALL	Body	Body Control Module			V																													V			V																						
K	2011	ALL	Body	Digital Radio Receiver																																																								
K	2011	ALL	Body	Distance Sensing Cruise Control														V		V																																								
K	2011	ALL	Body	Driver Door Switch																																																								
K	2011	ALL	Body	Driver Position Module																					V	V																																			
K	2011	ALL	Body	CJ2 Dual Zone HVAC Auto																																																								
K	2011	ALL	Body	CJ4 Tri Zone HVAC Auto																																																								
K	2011	ALL	Body	Inside Rear View Mirror Module																																																								
K	2011	ALL	Body	Instrument Panel Cluster																																																								
K	2011	ALL	Body	Left Side Object Detection Module																																																								
K	2011	ALL	Body	Park Assist Module																																																								
K	2011	ALL	Body	Passenger Door Switch																																																								
K	2011	ALL	Body	Passenger Presence System																																																								
K	2011	ALL	Body	Radio																																																								
K	2011	ALL	Body	Rear Heated Seat Module																																																								
K	2011	ALL	Body	Right Side Object Detection Module																																																								
K	2011	ALL	Body	Supplemental Inflatable Restraint																			V																																						
K	2011	ALL	Body	Theft Deterrent Module		V																																																							
K	2011	ALL	Body	TV Antenna Module																																																								
K	2011	ALL	Body	Vehicle Comm. Interface Module																																															V		V							
K	2011	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																								
K	2016	CT6	Powertrain	(X) 2.0L LTG Engine Control Module																																																								
K	2016	CT6	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
K	2016	CT6	Powertrain	(6) 3.0L LGW Engine Control Module																																																								
K	2016	CT6	Powertrain	(6) 3.0L LGW Transmission Control Module																																																								
K	2016	CT6	Powertrain	(S) 3.6L LGX Engine Control Module																																																								
K	2016	CT6	Powertrain	(S) 3.6L LGX Transmission Control Module																																																								
K	2016	CT6	Powertrain	Transfer Case Control Module																																																								
K	2016	CT6	Chassis	Electronic Brake Control Module																																																								
K	2016	CT6	Chassis	Brake Booster Control Module																																																								
K	2016	CT6	Chassis	Power Steering Control Module																																																								
K	2016	CT6	Chassis	Rear Wheel Steering Control Module																																																								
K	2016	CT6	Chassis	Suspension Control Module																																																								
K	2016	CT6	Body	Body Control Module																																																								
K	2016	CT6	Body	Serial Data Gateway Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2016	CT6	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	CT6	Body	Passenger Presence Module																																																											
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Left																																																										
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Right																																																										
K	2016	CT6	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
K	2016	CT6	Body	Instrument Cluster Full Screen Display (UDV)																																																										
K	2016	CT6	Body	Radio Controls																																																										
K	2016	CT6	Body	HVAC Controls																																																										
K	2016	CT6	Body	Active Safety Control Module																																																										
K	2016	CT6	Body	Video Processing Control Module																																																										
K	2016	CT6	Body	Headlamp Control Module																																																										
K	2016	CT6	Body	Trailer Interface Control Module																																																										
K	2016	CT6	Body	Radio																																																										
K	2016	CT6	Body	Amplifier																																																										
K	2016	CT6	Body	Infotainment Control Touchpad																																																										
K	2016	CT6	Body	Human Machine Interface Control Module																																																										
K	2016	CT6	Body	Navigation Control Module																																																										
K	2016	CT6	Body	Telematics Communication Interface Control Module																																																										
K	2016	CT6	Body	HVAC Control Module																																																										
K	2016	CT6	Body	Liftgate Control Module																																																										
K	2016	CT6	Body	Seat Memory Control Module - Passenger																																																										
K	2016	CT6	Body	Seat Memory Control Module - Left Rear																																																										
K	2016	CT6	Body	Seat Memory Control Module - Driver																																																										
K	2016	CT6	Body	Seat Memory Control Module - Right Rear																																																										
K	2016	CT6	Body	Keyless Entry Control Module																																																										
K	2016	CT6	Body	Left Side Object Detection Control Module																																																										
K	2016	CT6	Body	Parking Assist Control Module																																																										
K	2016	CT6	Body	Frontview Camera Module																																																										
K	2016	CT6	Body	Long Range Radar Sensor Module																																																										
K	2016	CT6	Body	Left Front Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Right Front Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Rear Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Night Vision Camera Control Module																																																										
R	2014	ELR	Powertrain	Engine Control Module																																																										
R	2014	ELR	Powertrain	Trasmission Control Module																																																										
R	2014	ELR	Powertrain	Chassis Control Module																																																										
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module																																																										
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2014	ELR	Powertrain	Drive Motor Control Module 1																																																										
R	2014	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2014	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2014	ELR	Chassis	Electronic Brake Control Module																																																										
R	2014	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2014	ELR	Chassis	Parking Brake Control Module																																																										
R	2014	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2014	ELR	Chassis	Power Steering Control Module																																																										
R	2014	ELR	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2014	ELR	Chassis	Suspension Control Module																																																										
R	2014	ELR	Body	Body Control Module																																																										
R	2014	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2014	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2014	ELR	Body	Passenger Presence Module																																																										
R	2014	ELR	Body	Instrument Cluster																																																										
R	2014	ELR	Body	Radio/HVAC Control																																																										
R	2014	ELR	Body	Radio																																																										
R	2014	ELR	Body	Amplifier																																																										
R	2014	ELR	Body	Human Machine Interface Control Module																																																										
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	ELR	Body	HVAC Control Module																																																										
R	2014	ELR	Body	Electric A/C Compressor Control Module																																																										
R	2014	ELR	Body	Coolant Heater Control Module																																																										
R	2014	ELR	Body	Seat Memory Control Module - Driver																																																										
R	2014	ELR	Body	Keyless Entry Control Module																																																										
R	2014	ELR	Body	Right Side Object Detection Control Module																																																										
R	2014	ELR	Body	Left Side Object Detection Control Module																																																										
R	2014	ELR	Body	Parking Assist Control Module																																																										
R	2014	ELR	Body	Frontview Camera Module																																																										
R	2014	ELR	Body	Steering Column Lock Control Module																																																										
R	2014	ELR	Body	Battery Charger Control Module																																																										
R	2014	ELR	Body	Battery Energy Control Module																																																										
R	2015	ELR	Powertrain	Engine Control Module																																																										
R	2015	ELR	Powertrain	Trasmission Control Module																																																										
R	2015	ELR	Powertrain	Chassis Control Module																																																										
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module																																																										
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2015	ELR	Powertrain	Drive Motor Control Module 1																																																										
R	2015	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2015	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2015	ELR	Chassis	Electronic Brake Control Module																																																										
R	2015	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2015	ELR	Chassis	Parking Brake Control Module																																																										
R	2015	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2015	ELR	Chassis	Power Steering Control Module																																																										
R	2015	ELR	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2015	ELR	Chassis	Suspension Control Module																																																										
R	2015	ELR	Body	Body Control Module																																																										
R	2015	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2015	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	ELR	Body	Passenger Presence Module																																																										
R	2015	ELR	Body	Instrument Cluster																																																										
R	2015	ELR	Body	Radio/HVAC Control																																																										
R	2015	ELR	Body	Headlamp Control Module																																																										
R	2015	ELR	Body	Radio																																																										
R	2015	ELR	Body	Amplifier																																																										
R	2015	ELR	Body	Human Machine Interface Control Module																																																										
R	2015	ELR	Body	Telematics Communication Interface Control Module																																																										
R	2015	ELR	Body	HVAC Control Module																																																										
R	2015	ELR	Body	Electric A/C Compressor Control Module																																																										
R	2015	ELR	Body	Coolant Heater Control Module																																																										
R	2015	ELR	Body	Seat Memory Control Module - Driver																																																										
R	2015	ELR	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2015	ELR	Body	Right Side Object Detection Control Module																																																										
R	2015	ELR	Body	Left Side Object Detection Control Module																																																										
R	2015	ELR	Body	Parking Assist Control Module																																																										
R	2015	ELR	Body	Frontview Camera Module																																																										
R	2015	ELR	Body	Steering Column Lock Control Module																																																										
R	2015	ELR	Body	Battery Charger Control Module																																																										
R	2015	ELR	Body	Battery Energy Control Module																																																										
R	2016	ELR	Powertrain	Engine Control Module																																																										
R	2016	ELR	Powertrain	Trasmission Control Module																																																										
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module																																																										
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2016	ELR	Powertrain	Drive Motor Control Module 1																																																										
R	2016	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2016	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2016	ELR	Chassis	Electronic Brake Control Module																																																										
R	2016	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2016	ELR	Chassis	Parking Brake Control Module																																																										
R	2016	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2016	ELR	Chassis	Power Steering Control Module																																																										
R	2016	ELR	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2016	ELR	Chassis	Suspension Control Module																																																										
R	2016	ELR	Body	Body Control Module																																																										
R	2016	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2016	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	ELR	Body	Passenger Presence Module																																																										
R	2016	ELR	Body	Instrument Cluster																																																										
R	2016	ELR	Body	Radio/HVAC Control																																																										
R	2016	ELR	Body	Headlamp Control Module																																																										
R	2016	ELR	Body	Radio																																																										
R	2016	ELR	Body	Amplifier																																																										
R	2016	ELR	Body	Human Machine Interface Control Module																																																										
R	2016	ELR	Body	Telematics Communication Interface Control Module																																																										
R	2016	ELR	Body	HVAC Control Module																																																										
R	2016	ELR	Body	Electric A/C Compressor Control Module																																																										
R	2016	ELR	Body	Coolant Heater Control Module																																																										
R	2016	ELR	Body	Seat Memory Control Module - Driver																																																										
R	2016	ELR	Body	Keyless Entry Control Module																																																										
R	2016	ELR	Body	Left Side Object Detection Control Module																																																										
R	2016	ELR	Body	Parking Assist Control Module																																																										
R	2016	ELR	Body	Frontview Camera Module																																																										
R	2016	ELR	Body	Steering Column Lock Control Module																																																										
R	2016	ELR	Body	Battery Charger Control Module																																																										
R	2016	ELR	Body	Battery Energy Control Module																																																										
Y	2004	ALL	Powertrain	Engine Control Module					V	V																																																				
Y	2004	ALL	Powertrain	Automatic Transmission																																																										
Y	2004	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
Y	2004	ALL	Chassis	Electronic Suspension Control																																																										
Y	2004	ALL	Chassis	Steering Wheel and Column																																																										
Y	2004	ALL	Body	Amplifier (Bose)																																																										
Y	2004	ALL	Body	Body Control Module			V								V																							V																							
Y	2004	ALL	Body	CD Changer																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Y	2004	ALL	Body	Digital Radio Receiver																																																									
Y	2004	ALL	Body	Distance Sensing Cruise Control														V		V																																									
Y	2004	ALL	Body	Driver Door Module																																																										
Y	2004	ALL	Body	Driver Door Switch																																																										
Y	2004	ALL	Body	Driver Position Module																			V	V	V	V																																					
Y	2004	ALL	Body	Folding Top Module																																																										
Y	2004	ALL	Body	Head Up Display																																																										
Y	2004	ALL	Body	HVAC Control Module																			V																																								
Y	2004	ALL	Body	Instrument Panel Cluster																																																										
Y	2004	ALL	Body	Navigation Radio								V																																																		
Y	2004	ALL	Body	Passenger Door Module																																																										
Y	2004	ALL	Body	Remote Control Door Lock Receiver																																											V															
Y	2004	ALL	Body	Steering Column Lock Module																																																										
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2005	ALL	Powertrain	Engine Control Module					V	V																																																				
Y	2005	ALL	Powertrain	Automatic Transmission																																																										
Y	2005	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
Y	2005	ALL	Chassis	Electronic Suspension Control																																																											
Y	2005	ALL	Chassis	Steering Wheel and Column																																																											
Y	2005	ALL	Body	Amplifier (Bose)																																																											
Y	2005	ALL	Body	Body Control Module			V								V																								V																								
Y	2005	ALL	Body	CD Changer																																																										
Y	2005	ALL	Body	Digital Radio Receiver																																																											
Y	2005	ALL	Body	Distance Sensing Cruise Control														V		V																																										
Y	2005	ALL	Body	Driver Door Module																																																											
Y	2005	ALL	Body	Driver Door Switch																																																											
Y	2005	ALL	Body	Driver Position Module																			V	V	V	V																																					
Y	2005	ALL	Body	Folding Top Module																																																											
Y	2005	ALL	Body	Head Up Display																																																											
Y	2005	ALL	Body	HVAC Control Module																			V																																								
Y	2005	ALL	Body	Instrument Panel Cluster																																																											
Y	2005	ALL	Body	Navigation Radio								V																																																		
Y	2005	ALL	Body	Passenger Door Module																																																											
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																											V															
Y	2005	ALL	Body	Steering Column Lock Module																																																											
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2006	(YV)XLR	Powertrain	Engine Control Module					V	V																																																				
Y	2006	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																											
Y	2006	(YV)XLR	Powertrain	Automatic Transmission																																																											
Y	2006	(YV)XLR	Chassis	Electronic Brake Control Module											V	V	V																																													
Y	2006	(YV)XLR	Chassis	Electronic Suspension Control																																																											
Y	2006	(YV)XLR	Chassis	Steering Wheel and Column																																																											
Y	2006	(YV)XLR	Body	Amplifier (Bose)																																																											
Y	2006	(YV)XLR	Body	Body Control Module			V								V																								V																								
Y	2006	(YV)XLR	Body	CD Changer																																																											
Y	2006	(YV)XLR	Body	Digital Radio Receiver																																																											
Y	2006	(YV)XLR	Body	Distance Sensing Cruise Control														V		V																																										
Y	2006	(YV)XLR	Body	Driver Door Module																																																											
Y	2006	(YV)XLR	Body	Driver Door Switch																																																											
Y	2006	(YV)XLR	Body	Driver Position Module																			V	V	V	V																																					
Y	2006	(YV)XLR	Body	Folding Top Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Y	2006	(YV)XLR	Body	Headlamp Control Module																																																									
Y	2006	(YV)XLR	Body	Head Up Display																																																									
Y	2006	(YV)XLR	Body	HVAC Control Module																			V																																						
Y	2006	(YV)XLR	Body	Instrument Panel Cluster																																																									
Y	2006	(YV)XLR	Body	Navigation Radio								V																																																	
Y	2006	(YV)XLR	Body	Passenger Door Module																																																									
Y	2006	(YV)XLR	Body	Remote Control Door Lock Receiver																																											V														
Y	2006	(YV)XLR	Body	Steering Column Lock Module																																																									
Y	2006	(YV)XLR	Body	Supplemental Inflatable Restraint	V																																																								
Y	2006	(YX)XLR-V	Powertrain	Engine Control Module					V																																																				V
Y	2006	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																									
Y	2006	(YX)XLR-V	Powertrain	Automatic Transmission																																																									
Y	2006	(YX)XLR-V	Chassis	Electronic Brake Control Module											V	V	V																																											
Y	2006	(YX)XLR-V	Chassis	Electronic Suspension Control																																																									
Y	2006	(YX)XLR-V	Chassis	Steering Wheel and Column																																																									
Y	2006	(YX)XLR-V	Body	Amplifier (Bose)																																																									
Y	2006	(YX)XLR-V	Body	Body Control Module			V								V																								V																						
Y	2006	(YX)XLR-V	Body	CD Changer																																																									
Y	2006	(YX)XLR-V	Body	Digital Radio Receiver																																																									
Y	2006	(YX)XLR-V	Body	Distance Sensing Cruise Control														V		V																																								
Y	2006	(YX)XLR-V	Body	Driver Door Module																																																									
Y	2006	(YX)XLR-V	Body	Driver Door Switch																																																									
Y	2006	(YX)XLR-V	Body	Driver Position Module																			V	V	V	V																																			
Y	2006	(YX)XLR-V	Body	Folding Top Module																																																									
Y	2006	(YX)XLR-V	Body	Headlamp Control Module																																																									
Y	2006	(YX)XLR-V	Body	Head Up Display																																																									
Y	2006	(YX)XLR-V	Body	HVAC Control Module																			V																																						
Y	2006	(YX)XLR-V	Body	Instrument Panel Cluster																																																									
Y	2006	(YX)XLR-V	Body	Navigation Radio								V																																																	
Y	2006	(YX)XLR-V	Body	Passenger Door Module																																																									
Y	2006	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																											V														
Y	2006	(YX)XLR-V	Body	Steering Column Lock Module																																																									
Y	2006	(YX)XLR-V	Body	Supplemental Inflatable Restraint	V																																																								
Y	2007	(YV)XLR	Powertrain	Engine Control Module					V																																														V				V
Y	2007	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																									
Y	2007	(YV)XLR	Powertrain	Transmission Control Module																																																									
Y	2007	(YV)XLR	Chassis	Electronic Brake Control Module											V	V	V																																											
Y	2007	(YV)XLR	Chassis	Electronic Suspension Control																																																									
Y	2007	(YV)XLR	Body	Amplifier (Bose)																																																									
Y	2007	(YV)XLR	Body	Body Control Module			V								V																								V																						
Y	2007	(YV)XLR	Body	CD Changer																																																									
Y	2007	(YV)XLR	Body	Digital Radio Receiver																																																									
Y	2007	(YV)XLR	Body	Distance Sensing Cruise Control														V		V																																								
Y	2007	(YV)XLR	Body	Driver Door Module																																																									
Y	2007	(YV)XLR	Body	Driver Door Switch																																																									
Y	2007	(YV)XLR	Body	Driver Position Module																			V	V	V	V																																			
Y	2007	(YV)XLR	Body	Folding Top Module																																																									
Y	2007	(YV)XLR	Body	Headlamp Control Module																																																									
Y	2007	(YV)XLR	Body	Head Up Display																																																									
Y	2007	(YV)XLR	Body	HVAC Control Module																			V																																						
Y	2007	(YV)XLR	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Y	2007	(YV)XLR	Body	Navigation Radio								V																																																
Y	2007	(YV)XLR	Body	Passenger Door Module																																																									
Y	2007	(YV)XLR	Body	Remote Control Door Lock Receiver																																											V													
Y	2007	(YV)XLR	Body	Steering Column Lock Module																																																								
Y	2007	(YV)XLR	Body	Supplemental Inflatable Restraint	V																																																							
Y	2007	(YX)XLR-V	Powertrain	Engine Control Module					V																																															V			V
Y	2007	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																								
Y	2007	(YX)XLR-V	Powertrain	Transmission Control Module																																																								
Y	2007	(YX)XLR-V	Chassis	Electronic Brake Control Module											V	V	V																																										
Y	2007	(YX)XLR-V	Chassis	Electronic Suspension Control																																																								
Y	2007	(YX)XLR-V	Body	Amplifier (Bose)																																																								
Y	2007	(YX)XLR-V	Body	Body Control Module			V								V																								V																					
Y	2007	(YX)XLR-V	Body	CD Changer																																																								
Y	2007	(YX)XLR-V	Body	Digital Radio Receiver																																																								
Y	2007	(YX)XLR-V	Body	Distance Sensing Cruise Control														V		V																																							
Y	2007	(YX)XLR-V	Body	Driver Door Module																																																								
Y	2007	(YX)XLR-V	Body	Driver Door Switch																																																								
Y	2007	(YX)XLR-V	Body	Driver Position Module																			V	V	V	V																																		
Y	2007	(YX)XLR-V	Body	Folding Top Module																																																								
Y	2007	(YX)XLR-V	Body	Headlamp Control Module																																																								
Y	2007	(YX)XLR-V	Body	Head Up Display																																																								
Y	2007	(YX)XLR-V	Body	HVAC Control Module																			V																																					
Y	2007	(YX)XLR-V	Body	Instrument Panel Cluster																																																								
Y	2007	(YX)XLR-V	Body	Navigation Radio								V																																																
Y	2007	(YX)XLR-V	Body	Passenger Door Module																																																								
Y	2007	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																											V													
Y	2007	(YX)XLR-V	Body	Steering Column Lock Module																																																								
Y	2007	(YX)XLR-V	Body	Supplemental Inflatable Restraint	V																																																							
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module					V																																															V			V
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																								
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																								
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V																																															V			V
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
Y	2008	ALL	Chassis	Electronic Brake Control Module											V	V	V																																										
Y	2008	ALL	Chassis	Electronic Suspension Control																																																								
Y	2008	ALL	Body	Amplifier (Bose)																																																								
Y	2008	ALL	Body	Body Control Module			V								V																								V																					
Y	2008	ALL	Body	CD Changer																																																								
Y	2008	ALL	Body	Digital Radio Receiver																																																								
Y	2008	ALL	Body	Distance Sensing Cruise Control														V		V																																							
Y	2008	ALL	Body	Driver Door Module																																																								
Y	2008	ALL	Body	Driver Door Switch																																																								
Y	2008	ALL	Body	Driver Position Module																			V	V	V	V																																		
Y	2008	ALL	Body	Folding Top Module																																																								
Y	2008	ALL	Body	Headlamp Control Module																																																								
Y	2008	ALL	Body	Head Up Display																																																								
Y	2008	ALL	Body	HVAC Control Module																			V																																					
Y	2008	ALL	Body	Instrument Panel Cluster																																																								
Y	2008	ALL	Body	Navigation Radio								V																																																
Y	2008	ALL	Body	Passenger Door Module																																																								
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																											V													

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Y	2008	ALL	Body	Steering Column Lock Module																																																								
Y	2008	ALL	Body	Supplemental Inflatable Restraint	V																																																							
Y	2008	ALL	Body	Vehicle Comm. Interface Module																																																V	V	V						
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module					V																																														V			V
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																								
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																								
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V																																														V			V
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
Y	2009	ALL	Chassis	Electronic Brake Control Module											V	V	V																																											
Y	2009	ALL	Chassis	Electronic Suspension Control																																																								
Y	2009	ALL	Body	Amplifier (Bose)																																																								
Y	2009	ALL	Body	Body Control Module			V								V																								V																					
Y	2009	ALL	Body	CD Changer																																																								
Y	2009	ALL	Body	Digital Radio Receiver																																																								
Y	2009	ALL	Body	Distance Sensing Cruise Control														V		V																																								
Y	2009	ALL	Body	Driver Door Module																																																								
Y	2009	ALL	Body	Driver Door Switch																																																								
Y	2009	ALL	Body	Driver Position Module																			V	V	V	V																																		
Y	2009	ALL	Body	Folding Top Module																																																								
Y	2009	ALL	Body	Headlamp Control Module																																																								
Y	2009	ALL	Body	Head Up Display																																																								
Y	2009	ALL	Body	HVAC Control Module																			V																																					
Y	2009	ALL	Body	Instrument Panel Cluster																																																								
Y	2009	ALL	Body	Navigation Radio								V																																																
Y	2009	ALL	Body	Passenger Door Module																																																								
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																										V														
Y	2009	ALL	Body	Steering Column Lock Module																																																								
Y	2009	ALL	Body	Supplemental Inflatable Restraint	V																																																							
1	2013	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
1	2013	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
1	2013	XTS	Powertrain	Fuel Pump Control Module																																																								
1	2013	XTS	Powertrain	Rear Differential Clutch Control Module																																																								
1	2013	XTS	Chassis	Electronic Brake Control Module																																																								
1	2013	XTS	Chassis	Parking Brake Control Module																																																								
1	2013	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																								
1	2013	XTS	Chassis	Power Steering Control Module																																																								
1	2013	XTS	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2013	XTS	Chassis	Suspension Control Module																																																								
1	2013	XTS	Body	Body Control Module																																																								
1	2013	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2013	XTS	Body	Passenger Presence Module																																																								
1	2013	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																								
1	2013	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																								
1	2013	XTS	Body	Radio/HVAC Control																																																								
1	2013	XTS	Body	Active Safety Control Module																																																								
1	2013	XTS	Body	Headlamp Control Module																																																								
1	2013	XTS	Body	Radio																																																								
1	2013	XTS	Body	Amplifier																																																								
1	2013	XTS	Body	Human Machine Interface Control Module																																																								
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 9																																																								
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 10																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2013	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2013	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																									
1	2013	XTS	Body	Seat Memory Control Module																																																									
1	2013	XTS	Body	Keyless Entry Control Module																																																									
1	2013	XTS	Body	Right Side Object Detection Control Module																																																									
1	2013	XTS	Body	Left Side Object Detection Control Module																																																									
1	2013	XTS	Body	Parking Assist Control Module																																																									
1	2013	XTS	Body	Frontview Camera Module																																																									
1	2013	XTS	Body	Long Range Radar Sensor Module																																																									
1	2013	XTS	Body	Left Front Short Range Radar Sensor Module																																																									
1	2013	XTS	Body	Right Front Short Range Radar Sensor Module																																																									
1	2013	XTS	Body	Rear Short Range Radar Sensor Module																																																									
1	2014	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																									
1	2014	XTS	Powertrain	(8) 3.6L LF3 Chassis Control Module																																																									
1	2014	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																									
1	2014	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
1	2014	XTS	Powertrain	(3) 3.6L LFX Chassis Control Module																																																									
1	2014	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
1	2014	XTS	Powertrain	Rear Differential Clutch Control Module																																																									
1	2014	XTS	Chassis	Electronic Brake Control Module																																																									
1	2014	XTS	Chassis	Parking Brake Control Module																																																									
1	2014	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																									
1	2014	XTS	Chassis	Power Steering Control Module																																																									
1	2014	XTS	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2014	XTS	Chassis	Suspension Control Module																																																									
1	2014	XTS	Body	Body Control Module																																																									
1	2014	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2014	XTS	Body	Passenger Presence Module																																																									
1	2014	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																									
1	2014	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																									
1	2014	XTS	Body	Radio/HVAC Control																																																									
1	2014	XTS	Body	Active Safety Control Module																																																									
1	2014	XTS	Body	Headlamp Control Module																																																									
1	2014	XTS	Body	Radio																																																									
1	2014	XTS	Body	Amplifier																																																									
1	2014	XTS	Body	Media Disc Player																																																									
1	2014	XTS	Body	Human Machine Interface Control Module																																																									
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 9																																																									
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2014	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2014	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																									
1	2014	XTS	Body	Seat Memory Control Module - Passenger																																																									
1	2014	XTS	Body	Seat Memory Control Module - Driver																																																									
1	2014	XTS	Body	Keyless Entry Control Module																																																									
1	2014	XTS	Body	Right Side Object Detection Control Module																																																									
1	2014	XTS	Body	Left Side Object Detection Control Module																																																									
1	2014	XTS	Body	Parking Assist Control Module																																																									
1	2014	XTS	Body	Frontview Camera Module																																																									
1	2014	XTS	Body	Long Range Radar Sensor Module																																																									
1	2014	XTS	Body	Left Front Short Range Radar Sensor Module																																																									
1	2014	XTS	Body	Right Front Short Range Radar Sensor Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2014	XTS	Body	Rear Short Range Radar Sensor Module																																																											
1	2015	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
1	2015	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
1	2015	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2015	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2015	XTS	Powertrain	Chassis Control Module																																																											
1	2015	XTS	Powertrain	Rear Differential Clutch Control Module																																																											
1	2015	XTS	Chassis	Electronic Brake Control Module																																																											
1	2015	XTS	Chassis	Parking Brake Control Module																																																											
1	2015	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2015	XTS	Chassis	Power Steering Control Module																																																											
1	2015	XTS	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2015	XTS	Chassis	Suspension Control Module																																																											
1	2015	XTS	Body	Body Control Module																																																											
1	2015	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	XTS	Body	Passenger Presence Module																																																											
1	2015	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
1	2015	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																											
1	2015	XTS	Body	Radio/HVAC Control																																																											
1	2015	XTS	Body	Active Safety Control Module																																																											
1	2015	XTS	Body	Radio																																																											
1	2015	XTS	Body	Amplifier																																																											
1	2015	XTS	Body	Media Disc Player																																																											
1	2015	XTS	Body	Human Machine Interface Control Module																																																											
1	2015	XTS	Body	Telematics Communication Interface Control Module																																																											
1	2015	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2015	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
1	2015	XTS	Body	Seat Memory Control Module - Passenger																																																											
1	2015	XTS	Body	Seat Memory Control Module - Driver																																																											
1	2015	XTS	Body	Keyless Entry Control Module																																																											
1	2015	XTS	Body	Right Side Object Detection Control Module																																																											
1	2015	XTS	Body	Left Side Object Detection Control Module																																																											
1	2015	XTS	Body	Parking Assist Control Module GMLAN																																																											
1	2015	XTS	Body	Parking Assist Control Module DID72History																																																											
1	2015	XTS	Body	Frontview Camera Module																																																											
1	2015	XTS	Body	Long Range Radar Sensor Module																																																											
1	2015	XTS	Body	Left Front Short Range Radar Sensor Module																																																											
1	2015	XTS	Body	Right Front Short Range Radar Sensor Module																																																											
1	2015	XTS	Body	Rear Short Range Radar Sensor Module																																																											
1	2016	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
1	2016	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
1	2016	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2016	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2016	XTS	Powertrain	Chassis Control Module																																																											
1	2016	XTS	Powertrain	Rear Differential Clutch Control Module																																																											
1	2016	XTS	Chassis	Electronic Brake Control Module																																																											
1	2016	XTS	Chassis	Parking Brake Control Module																																																											
1	2016	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2016	XTS	Chassis	Power Steering Control Module																																																											
1	2016	XTS	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	XTS	Chassis	Suspension Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2016	XTS	Body	Body Control Module																																																										
1	2016	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2016	XTS	Body	Passenger Presence Module																																																											
1	2016	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
1	2016	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																											
1	2016	XTS	Body	Radio/HVAC Control																																																											
1	2016	XTS	Body	Active Safety Control Module																																																											
1	2016	XTS	Body	Video Processing Control Module																																																											
1	2016	XTS	Body	Radio																																																											
1	2016	XTS	Body	Amplifier																																																											
1	2016	XTS	Body	Media Disc Player																																																											
1	2016	XTS	Body	Human Machine Interface Control Module																																																											
1	2016	XTS	Body	Telematics Communication Interface Control Module																																																											
1	2016	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2016	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
1	2016	XTS	Body	Seat Memory Control Module - Passenger																																																											
1	2016	XTS	Body	Seat Memory Control Module - Driver																																																											
1	2016	XTS	Body	Keyless Entry Control Module																																																											
1	2016	XTS	Body	Right Side Object Detection Control Module																																																											
1	2016	XTS	Body	Left Side Object Detection Control Module																																																											
1	2016	XTS	Body	Parking Assist Control Module																																																											
1	2016	XTS	Body	Frontview Camera Module																																																											
1	2016	XTS	Body	Steering Column Lock Control Module																																																											
1	2016	XTS	Body	Long Range Radar Sensor Module																																																											
1	2016	XTS	Body	Left Front Short Range Radar Sensor Module																																																											
1	2016	XTS	Body	Right Front Short Range Radar Sensor Module																																																											
1	2016	XTS	Body	Rear Short Range Radar Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Engine Mount																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Engine Mount																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Engine Mount																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2013	ATS	Powertrain	Transfer Case Control Module																																																										
A	2013	ATS	Chassis	Electronic Brake Control Module																																																										
A	2013	ATS	Chassis	Parking Brake Control Module																																																										
A	2013	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	ATS	Chassis	Power Steering Control Module																																																										
A	2013	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	ATS	Chassis	Suspension Control Module																																																										
A	2013	ATS	Body	Body Control Module Halogen																																																										
A	2013	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2013	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	ATS	Body	Passenger Presence Module																																																										
A	2013	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2013	ATS	Body	Instrument Cluster																																																										
A	2013	ATS	Body	Radio/HVAC Control																																																										
A	2013	ATS	Body	Active Safety Control Module																																																										
A	2013	ATS	Body	Headlamp Control Module																																																										
A	2013	ATS	Body	Trailer Interface Control Module																																																										
A	2013	ATS	Body	Radio																																																										
A	2013	ATS	Body	Amplifier																																																										
A	2013	ATS	Body	Human Machine Interface Control Module																																																										
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2013	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2013	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2013	ATS	Body	Seat Memory Control Module																																																										
A	2013	ATS	Body	Keyless Entry Type Without Passive Entry																																																										
A	2013	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
A	2013	ATS	Body	Right Side Object Detection Control Module																																																										
A	2013	ATS	Body	Left Side Object Detection Control Module																																																										
A	2013	ATS	Body	Parking Assist Control Module																																																										
A	2013	ATS	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2013	ATS	Body	Steering Column Lock Control Module																																																											
A	2013	ATS	Body	Long Range Radar Sensor Module																																																												
A	2013	ATS	Body	Left Front Short Range Radar Sensor Module																																																											
A	2013	ATS	Body	Right Front Short Range Radar Sensor Module																																																											
A	2013	ATS	Body	Rear Short Range Radar Sensor Module																																																											
A	2014	ATS	Powertrain	(X) 2.0L LTG Engine Control Module																																																											
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																											
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																											
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2014	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
A	2014	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																											
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																											
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																											
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2014	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
A	2014	ATS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																											
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																											
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2014	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
A	2014	ATS	Powertrain	Transfer Case Control Module																																																												
A	2014	ATS	Chassis	Electronic Brake Control Module																																																												
A	2014	ATS	Chassis	Parking Brake Control Module																																																												
A	2014	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2014	ATS	Chassis	Power Steering Control Module																																																												
A	2014	ATS	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2014	ATS	Chassis	Suspension Control Module																																																												
A	2014	ATS	Body	Body Control Module Halogen																																																												
A	2014	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
A	2014	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2014	ATS	Body	Passenger Presence Module																																																											
A	2014	ATS	Body	Pedestrian Impact Detection Module																																																											
A	2014	ATS	Body	Instrument Cluster																																																											
A	2014	ATS	Body	Radio/HVAC Control																																																											
A	2014	ATS	Body	Active Safety Control Module																																																											
A	2014	ATS	Body	Headlamp Control Module																																																											
A	2014	ATS	Body	Trailer Interface Control Module																																																											
A	2014	ATS	Body	Radio																																																											
A	2014	ATS	Body	Amplifier																																																											
A	2014	ATS	Body	Media Disc Player																																																											
A	2014	ATS	Body	Human Machine Interface Control Module																																																											
A	2014	ATS	Body	Navigation Control Module																																																											
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2014	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
A	2014	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
A	2014	ATS	Body	Seat Memory Control Module - Driver																																																											
A	2014	ATS	Body	Keyless Entry Type Without Passive Entry																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2014	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
A	2014	ATS	Body	Right Side Object Detection Control Module																																																											
A	2014	ATS	Body	Left Side Object Detection Control Module																																																											
A	2014	ATS	Body	Parking Assist Control Module																																																											
A	2014	ATS	Body	Frontview Camera Module																																																											
A	2014	ATS	Body	Steering Column Lock Control Module																																																											
A	2014	ATS	Body	Long Range Radar Sensor Module																																																											
A	2014	ATS	Body	Left Front Short Range Radar Sensor Module																																																											
A	2014	ATS	Body	Right Front Short Range Radar Sensor Module																																																											
A	2014	ATS	Body	Rear Short Range Radar Sensor Module																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Maunal Transmission																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
A	2014	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
A	2014	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																											
A	2014	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
A	2014	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2014	CTS	Powertrain	Transfer Case Control Module																																																												
A	2014	CTS	Chassis	Electronic Brake Control Module																																																												
A	2014	CTS	Chassis	Parking Brake Control Module																																																												
A	2014	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2014	CTS	Chassis	Power Steering Control Module																																																												
A	2014	CTS	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2014	CTS	Chassis	Suspension Control Module																																																												
A	2014	CTS	Body	Body Control Module Headlamp Type Halogen																																																												
A	2014	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
A	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2014	CTS	Body	Passenger Presence Module																																																												
A	2014	CTS	Body	Pedestrian Impact Detection Module																																																												
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Left																																																												
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Right																																																												
A	2014	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
A	2014	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
A	2014	CTS	Body	Radio/HVAC Control																																																												
A	2014	CTS	Body	Active Safety Control Module																																																												
A	2014	CTS	Body	Headlamp Control Module																																																												
A	2014	CTS	Body	Trailer Interface Control Module																																																												
A	2014	CTS	Body	Radio																																																												
A	2014	CTS	Body	Amplifier																																																												
A	2014	CTS	Body	Human Machine Interface Control Module																																																												
A	2014	CTS	Body	Navigation Control Module																																																												
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																												
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2014	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
A	2014	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
A	2014	CTS	Body	Seat Memory Control Module - Driver																																																											
A	2014	CTS	Body	Keyless Entry Control Module																																																											
A	2014	CTS	Body	Right Side Object Detection Control Module																																																											
A	2014	CTS	Body	Left Side Object Detection Control Module																																																											
A	2014	CTS	Body	Parking Assist Control Module																																																											
A	2014	CTS	Body	Frontview Camera Module																																																											
A	2014	CTS	Body	Steering Column Lock Control Module																																																											
A	2014	CTS	Body	Long Range Radar Sensor Module																																																											
A	2014	CTS	Body	Left Front Short Range Radar Sensor Module																																																											
A	2014	CTS	Body	Right Front Short Range Radar Sensor Module																																																											
A	2014	CTS	Body	Rear Short Range Radar Sensor Module																																																											
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																											
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																											
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2015	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
A	2015	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																											
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																											
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																											
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2015	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																											
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																											
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2015	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
A	2015	ATS	Powertrain	Transfer Case Control Module																																																											
A	2015	ATS	Chassis	Electronic Brake Control Module																																																											
A	2015	ATS	Chassis	Parking Brake Control Module																																																											
A	2015	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2015	ATS	Chassis	Power Steering Control Module																																																											
A	2015	ATS	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2015	ATS	Chassis	Suspension Control Module																																																											
A	2015	ATS	Body	Body Control Module Halogen																																																											
A	2015	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
A	2015	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2015	ATS	Body	Passenger Presence Module																																																											
A	2015	ATS	Body	Pedestrian Impact Detection Module																																																											
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Left																																																											
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Right																																																											
A	2015	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
A	2015	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																											
A	2015	ATS	Body	Radio/HVAC Control																																																											
A	2015	ATS	Body	Active Safety Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2015	ATS	Body	Headlamp Control Module																																																										
A	2015	ATS	Body	Trailer Interface Control Module																																																											
A	2015	ATS	Body	Radio																																																										
A	2015	ATS	Body	Amplifier																																																										
A	2015	ATS	Body	Media Disc Player																																																										
A	2015	ATS	Body	Human Machine Interface Control Module																																																											
A	2015	ATS	Body	Navigation Control Module																																																											
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																											
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2015	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
A	2015	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
A	2015	ATS	Body	Seat Memory Control Module - Driver																																																											
A	2015	ATS	Body	Keyless Entry Control Module Coupe																																																											
A	2015	ATS	Body	Keyless Entry Control Module Sadan																																																											
A	2015	ATS	Body	Right Side Object Detection Control Module																																																											
A	2015	ATS	Body	Left Side Object Detection Control Module																																																											
A	2015	ATS	Body	Parking Assist Control Module																																																											
A	2015	ATS	Body	Frontview Camera Module																																																											
A	2015	ATS	Body	Steering Column Lock Control Module																																																											
A	2015	ATS	Body	Long Range Radar Sensor Module																																																											
A	2015	ATS	Body	Left Front Short Range Radar Sensor Module																																																											
A	2015	ATS	Body	Right Front Short Range Radar Sensor Module																																																											
A	2015	ATS	Body	Rear Short Range Radar Sensor Module																																																											
A	2015	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																											
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Engine Mount																																																											
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2015	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
A	2015	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																											
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2015	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
A	2015	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																											
A	2015	CTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Engine Mount																																																											
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																											
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																											
A	2015	CTS	Powertrain	Transfer Case Control Module																																																											
A	2015	CTS	Chassis	Electronic Brake Control Module																																																											
A	2015	CTS	Chassis	Parking Brake Control Module																																																											
A	2015	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2015	CTS	Chassis	Power Steering Control Module																																																											
A	2015	CTS	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2015	CTS	Chassis	Suspension Control Module																																																											
A	2015	CTS	Body	Body Control Module Headlamp Type Halogen																																																											
A	2015	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
A	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2015	CTS	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2015	CTS	Body	Pedestrian Impact Detection Module																																																											
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Left																																																											
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Right																																																											
A	2015	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
A	2015	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																											
A	2015	CTS	Body	Active Safety Control Module																																																											
A	2015	CTS	Body	Trailer Interface Control Module																																																											
A	2015	CTS	Body	Radio																																																											
A	2015	CTS	Body	Amplifier																																																										
A	2015	CTS	Body	Human Machine Interface Control Module																																																											
A	2015	CTS	Body	Navigation Control Module																																																											
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																											
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2015	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
A	2015	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
A	2015	CTS	Body	Seat Memory Control Module - Driver																																																											
A	2015	CTS	Body	Keyless Entry Control Module																																																											
A	2015	CTS	Body	Right Side Object Detection Control Module																																																											
A	2015	CTS	Body	Left Side Object Detection Control Module																																																											
A	2015	CTS	Body	Parking Assist Control Module																																																											
A	2015	CTS	Body	Frontview Camera Module																																																											
A	2015	CTS	Body	Steering Column Lock Control Module																																																											
A	2015	CTS	Body	Long Range Radar Sensor Module																																																											
A	2015	CTS	Body	Left Front Short Range Radar Sensor Module																																																											
A	2015	CTS	Body	Right Front Short Range Radar Sensor Module																																																											
A	2015	CTS	Body	Rear Short Range Radar Sensor Module																																																											
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
A	2016	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
A	2016	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Automatic Transmission																																																											
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Manual Transmission																																																											
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Transmission Control Module																																																											
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																											
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																											
A	2016	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
A	2016	ATS	Powertrain	Transfer Case Control Module																																																											
A	2016	ATS	Powertrain	Rear Differential Clutch Control Module																																																											
A	2016	ATS	Chassis	Electronic Brake Control Module																																																											
A	2016	ATS	Chassis	Parking Brake Control Module																																																											
A	2016	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2016	ATS	Chassis	Power Steering Control Module																																																											
A	2016	ATS	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2016	ATS	Chassis	Suspension Control Module																																																											
A	2016	ATS	Body	Body Control Module Halogen																																																											
A	2016	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
A	2016	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2016	ATS	Body	Passenger Presence Module																																																											
A	2016	ATS	Body	Pedestrian Impact Detection Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2016	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2016	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2016	ATS	Body	Radio/HVAC Control																																																										
A	2016	ATS	Body	Vehicle Performance Data Recorder																																																										
A	2016	ATS	Body	Trailer Interface Control Module																																																										
A	2016	ATS	Body	Radio																																																										
A	2016	ATS	Body	Amplifier																																																										
A	2016	ATS	Body	Rear Audio Control Module																																																										
A	2016	ATS	Body	Media Disc Player																																																										
A	2016	ATS	Body	Human Machine Interface Control Module																																																										
A	2016	ATS	Body	Navigation Control Module																																																										
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2016	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2016	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2016	ATS	Body	Seat Memory Control Module - Passenger																																																										
A	2016	ATS	Body	Seat Memory Control Module - Driver																																																										
A	2016	ATS	Body	Keyless Entry Control Module Coupe																																																										
A	2016	ATS	Body	Keyless Entry Control Module Sadan																																																										
A	2016	ATS	Body	Right Side Object Detection Control Module																																																										
A	2016	ATS	Body	Left Side Object Detection Control Module																																																										
A	2016	ATS	Body	Parking Assist Control Module																																																										
A	2016	ATS	Body	Frontview Camera Module																																																										
A	2016	ATS	Body	Steering Column Lock Control Module																																																										
A	2016	ATS	Body	Long Range Radar Sensor Module																																																										
A	2016	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2016	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2016	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2016	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
A	2016	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2016	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
A	2016	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
A	2016	CTS	Powertrain	(S) 3.6L LGX Engine Control Module																																																										
A	2016	CTS	Powertrain	(S) 3.6L LGX Transmission Control Module																																																										
A	2016	CTS	Powertrain	(6) 6.2L LT4 Engine Control Module																																																										
A	2016	CTS	Powertrain	(6) 6.2L LT4 Transmission Control Module																																																										
A	2016	CTS	Powertrain	Rear Differential Clutch Control Module																																																										
A	2016	CTS	Powertrain	Transfer Case Control Module																																																										
A	2016	CTS	Chassis	Electronic Brake Control Module																																																										
A	2016	CTS	Chassis	Parking Brake Control Module																																																										
A	2016	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2016	CTS	Chassis	Power Steering Control Module																																																										
A	2016	CTS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	CTS	Chassis	Suspension Control Module																																																										
A	2016	CTS	Body	Body Control Module Headlamp Type Halogen																																																										
A	2016	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2016	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	CTS	Body	Passenger Presence Module																																																										
A	2016	CTS	Body	Pedestrian Impact Detection Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2016	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2016	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2016	CTS	Body	Radio/HVAC Control																																																										
A	2016	CTS	Body	Vehicle Performance Data Recorder																																																										
A	2016	CTS	Body	Active Safety Control Module																																																										
A	2016	CTS	Body	Video Processing Control Module																																																										
A	2016	CTS	Body	Trailer Interface Control Module																																																										
A	2016	CTS	Body	Radio																																																										
A	2016	CTS	Body	Amplifier																																																										
A	2016	CTS	Body	Human Machine Interface Control Module																																																										
A	2016	CTS	Body	Navigation Control Module																																																										
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2016	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2016	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2016	CTS	Body	Seat Memory Control Module - Passenger																																																										
A	2016	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2016	CTS	Body	Keyless Entry Control Module																																																										
A	2016	CTS	Body	Right Side Object Detection Control Module																																																										
A	2016	CTS	Body	Left Side Object Detection Control Module																																																										
A	2016	CTS	Body	Parking Assist Control Module																																																										
A	2016	CTS	Body	Frontview Camera Module																																																										
A	2016	CTS	Body	Steering Column Lock Control Module																																																										
A	2016	CTS	Body	Long Range Radar Sensor Module																																																										
A	2016	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2016	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2016	CTS	Body	Rear Short Range Radar Sensor Module																																																										
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																										
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																										
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																										
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																										
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																										
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																										
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2004	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2004	(DM)CTS	Chassis	VES																																																										
D	2004	(DM)CTS	Body	Amplifier (Bose)																																																										
D	2004	(DM)CTS	Body	Amplifier (Delco)																																																										
D	2004	(DM)CTS	Body	Climate Control Panel																																																										
D	2004	(DM)CTS	Body	Dash Integration Module																																																										
D	2004	(DM)CTS	Body	Digital Radio Receiver																																																										
D	2004	(DM)CTS	Body	Driver Door Switch																																																										
D	2004	(DM)CTS	Body	Driver Door Module																																																										
D	2004	(DM)CTS	Body	Passenger Door Module																																																										
D	2004	(DM)CTS	Body	Left Rear Door Module																																																										
D	2004	(DM)CTS	Body	Right Rear Door Module																																																										
D	2004	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2004	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2004	(DM)CTS	Body	Instrument Panel Cluster																																																											
D	2004	(DM)CTS	Body	Memory Seat Module																																																												
D	2004	(DM)CTS	Body	Personalization																																																												
D	2004	(DM)CTS	Body	Rear Integration Module																																																												
D	2004	(DM)CTS	Body	Remote Function Actuation																																																												
D	2004	(DM)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2004	(DM)CTS	Body	TV Antenna Module																																																												
D	2004	(DM)CTS	Body	Vehicle Theft Deterrent																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																												
D	2004	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2004	(DR)CTS	Chassis	VES																																																												
D	2004	(DR)CTS	Body	Amplifier (Bose)																																																												
D	2004	(DR)CTS	Body	Amplifier (Delco)																																																												
D	2004	(DR)CTS	Body	Climate Control Panel																																																												
D	2004	(DR)CTS	Body	Dash Integration Module																																																												
D	2004	(DR)CTS	Body	Digital Radio Receiver																																																												
D	2004	(DR)CTS	Body	Driver Door Switch																																																												
D	2004	(DR)CTS	Body	Driver Door Module																																																												
D	2004	(DR)CTS	Body	Passenger Door Module																																																												
D	2004	(DR)CTS	Body	Left Rear Door Module																																																												
D	2004	(DR)CTS	Body	Right Rear Door Module																																																												
D	2004	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2004	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2004	(DR)CTS	Body	Instrument Panel Cluster																																																												
D	2004	(DR)CTS	Body	Memory Seat Module																																																												
D	2004	(DR)CTS	Body	Personalization																																																												
D	2004	(DR)CTS	Body	Rear Integration Module																																																												
D	2004	(DR)CTS	Body	Remote Function Actuation																																																												
D	2004	(DR)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2004	(DR)CTS	Body	TV Antenna Module																																																												
D	2004	(DR)CTS	Body	Vehicle Theft Deterrent																																																												
D	2004	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																												
D	2004	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																												
D	2004	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																												
D	2004	(DN)CTS-V	Chassis	VES																																																												
D	2004	(DN)CTS-V	Body	Amplifier (Bose)																																																												
D	2004	(DN)CTS-V	Body	Amplifier (Delco)																																																												
D	2004	(DN)CTS-V	Body	Climate Control Panel																																																												
D	2004	(DN)CTS-V	Body	Dash Integration Module																																																												
D	2004	(DN)CTS-V	Body	Digital Radio Receiver																																																												
D	2004	(DN)CTS-V	Body	Driver Door Switch																																																												
D	2004	(DN)CTS-V	Body	Driver Door Module																																																												
D	2004	(DN)CTS-V	Body	Passenger Door Module																																																												
D	2004	(DN)CTS-V	Body	Left Rear Door Module																																																												
D	2004	(DN)CTS-V	Body	Right Rear Door Module																																																												
D	2004	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2004	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																											
D	2004	(DN)CTS-V	Body	Instrument Panel Cluster																																																											
D	2004	(DN)CTS-V	Body	Memory Seat Module																																																											
D	2004	(DN)CTS-V	Body	Personalization																																																											
D	2004	(DN)CTS-V	Body	Rear Integration Module																																																											
D	2004	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																											
D	2004	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																											
D	2004	(DN)CTS-V	Body	TV Antenna Module																																																											
D	2004	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																											
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2005	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2005	(DM)CTS	Chassis	VES																																																											
D	2005	(DM)CTS	Body	Amplifier (Bose)																																																											
D	2005	(DM)CTS	Body	Amplifier (Delco)																																																											
D	2005	(DM)CTS	Body	Climate Control Panel																																																											
D	2005	(DM)CTS	Body	Dash Integration Module																																																											
D	2005	(DM)CTS	Body	Digital Radio Receiver																																																											
D	2005	(DM)CTS	Body	Driver Door Switch																																																											
D	2005	(DM)CTS	Body	Driver Door Module																																																											
D	2005	(DM)CTS	Body	Passenger Door Module																																																											
D	2005	(DM)CTS	Body	Left Rear Door Module																																																											
D	2005	(DM)CTS	Body	Right Rear Door Module																																																											
D	2005	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2005	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2005	(DM)CTS	Body	Instrument Panel Cluster																																																											
D	2005	(DM)CTS	Body	Memory Seat Module																																																											
D	2005	(DM)CTS	Body	Personalization																																																											
D	2005	(DM)CTS	Body	Rear Integration Module																																																											
D	2005	(DM)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DM)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2005	(DM)CTS	Body	TV Antenna Module																																																											
D	2005	(DM)CTS	Body	Vehicle Theft Deterrent																																																											
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2005	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2005	(DP)CTS	Chassis	VES																																																											
D	2005	(DP)CTS	Body	Amplifier (Bose)																																																											
D	2005	(DP)CTS	Body	Amplifier (Delco)																																																											
D	2005	(DP)CTS	Body	Climate Control Panel																																																											
D	2005	(DP)CTS	Body	Dash Integration Module																																																											
D	2005	(DP)CTS	Body	Digital Radio Receiver																																																											
D	2005	(DP)CTS	Body	Driver Door Switch																																																											
D	2005	(DP)CTS	Body	Driver Door Module																																																											
D	2005	(DP)CTS	Body	Passenger Door Module																																																											
D	2005	(DP)CTS	Body	Left Rear Door Module																																																											
D	2005	(DP)CTS	Body	Right Rear Door Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2005	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2005	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2005	(DP)CTS	Body	Instrument Panel Cluster																																																											
D	2005	(DP)CTS	Body	Memory Seat Module																																																											
D	2005	(DP)CTS	Body	Personalization																																																											
D	2005	(DP)CTS	Body	Rear Integration Module																																																											
D	2005	(DP)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DP)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2005	(DP)CTS	Body	TV Antenna Module																																																											
D	2005	(DP)CTS	Body	Vehicle Theft Deterrent																																																											
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2005	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2005	(DR)CTS	Chassis	VES																																																											
D	2005	(DR)CTS	Body	Amplifier (Bose)																																																											
D	2005	(DR)CTS	Body	Amplifier (Delco)																																																											
D	2005	(DR)CTS	Body	Climate Control Panel																																																											
D	2005	(DR)CTS	Body	Dash Integration Module																																																											
D	2005	(DR)CTS	Body	Digital Radio Receiver																																																											
D	2005	(DR)CTS	Body	Driver Door Switch																																																											
D	2005	(DR)CTS	Body	Driver Door Module																																																											
D	2005	(DR)CTS	Body	Passenger Door Module																																																											
D	2005	(DR)CTS	Body	Left Rear Door Module																																																											
D	2005	(DR)CTS	Body	Right Rear Door Module																																																											
D	2005	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2005	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2005	(DR)CTS	Body	Instrument Panel Cluster																																																											
D	2005	(DR)CTS	Body	Memory Seat Module																																																											
D	2005	(DR)CTS	Body	Personalization																																																											
D	2005	(DR)CTS	Body	Radio																																																											
D	2005	(DR)CTS	Body	Rear Integration Module																																																											
D	2005	(DR)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DR)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2005	(DR)CTS	Body	TV Antenna Module																																																											
D	2005	(DR)CTS	Body	Vehicle Theft Deterrent																																																											
D	2005	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																											
D	2005	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																											
D	2005	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																											
D	2005	(DN)CTS-V	Chassis	VES																																																											
D	2005	(DN)CTS-V	Body	Amplifier (Bose)																																																											
D	2005	(DN)CTS-V	Body	Amplifier (Delco)																																																											
D	2005	(DN)CTS-V	Body	Climate Control Panel																																																											
D	2005	(DN)CTS-V	Body	Dash Integration Module																																																											
D	2005	(DN)CTS-V	Body	Digital Radio Receiver																																																											
D	2005	(DN)CTS-V	Body	Driver Door Switch																																																											
D	2005	(DN)CTS-V	Body	Driver Door Module																																																											
D	2005	(DN)CTS-V	Body	Passenger Door Module																																																											
D	2005	(DN)CTS-V	Body	Left Rear Door Module																																																											
D	2005	(DN)CTS-V	Body	Right Rear Door Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2005	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																											
D	2005	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																											
D	2005	(DN)CTS-V	Body	Instrument Panel Cluster																																																											
D	2005	(DN)CTS-V	Body	Memory Seat Module																																																											
D	2005	(DN)CTS-V	Body	Personalization																																																											
D	2005	(DN)CTS-V	Body	Radio																																																											
D	2005	(DN)CTS-V	Body	Rear Integration Module																																																											
D	2005	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																											
D	2005	(DN)CTS-V	Body	TV Antenna Module																																																											
D	2005	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																											
D	2005	(DC)STS-V8	Powertrain	Engine Control Module																																																											
D	2005	(DC)STS-V8	Powertrain	Transmission Control Module																																																											
D	2005	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																											
D	2005	(DC)STS-V8	Chassis	Electronic Suspension Control																																																											
D	2005	(DC)STS-V8	Body	Amplifier (Bose)																																																											
D	2005	(DC)STS-V8	Body	Digital Radio Receiver																																																											
D	2005	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																											
D	2005	(DC)STS-V8	Body	Driver Door Module																																																											
D	2005	(DC)STS-V8	Body	Driver Door Switch																																																											
D	2005	(DC)STS-V8	Body	Driver Position Module																																																											
D	2005	(DC)STS-V8	Body	Headlamp Control Module																																																											
D	2005	(DC)STS-V8	Body	Head Up Display																																																											
D	2005	(DC)STS-V8	Body	HVAC Control Module																																																											
D	2005	(DC)STS-V8	Body	Instrument Panel Cluster																																																											
D	2005	(DC)STS-V8	Body	Instrument Panel Module																																																											
D	2005	(DC)STS-V8	Body	Left Rear Door Module																																																											
D	2005	(DC)STS-V8	Body	Passenger Door Module																																																											
D	2005	(DC)STS-V8	Body	Uplevel Radio																																																											
D	2005	(DC)STS-V8	Body	Navigation Radio																																																											
D	2005	(DC)STS-V8	Body	Rear Integration Module																																																											
D	2005	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DC)STS-V8	Body	Right Rear Door Module																																																											
D	2005	(DC)STS-V8	Body	Steering Column Lock Module																																																											
D	2005	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																											
D	2005	(DC)STS-V8	Body	TV Antenna Module																																																											
D	2005	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																											
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2005	(DW)STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
D	2005	(DW)STS	Chassis	Electronic Brake Control Module																																																											
D	2005	(DW)STS	Chassis	Electronic Suspension Control																																																											
D	2005	(DW)STS	Body	Amplifier (Bose)																																																											
D	2005	(DW)STS	Body	Digital Radio Receiver																																																											
D	2005	(DW)STS	Body	Distance Sensing Cruise Control																																																											
D	2005	(DW)STS	Body	Driver Door Module																																																											
D	2005	(DW)STS	Body	Driver Door Switch																																																											
D	2005	(DW)STS	Body	Driver Position Module																																																											
D	2005	(DW)STS	Body	Headlamp Control Module																																																											
D	2005	(DW)STS	Body	Head Up Display																																																											
D	2005	(DW)STS	Body	HVAC Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2005	(DW)STS	Body	Instrument Panel Cluster																																																										
D	2005	(DW)STS	Body	Instrument Panel Module																																																											
D	2005	(DW)STS	Body	Left Rear Door Module																																																											
D	2005	(DW)STS	Body	Passenger Door Module																																																											
D	2005	(DW)STS	Body	Uplevel Radio																																																											
D	2005	(DW)STS	Body	Navigation Radio																																																											
D	2005	(DW)STS	Body	Rear Integration Module																																																											
D	2005	(DW)STS	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DW)STS	Body	Right Rear Door Module																																																											
D	2005	(DW)STS	Body	Steering Column Lock Module																																																											
D	2005	(DW)STS	Body	Supplemental Inflatable Restraint																																																											
D	2005	(DW)STS	Body	TV Antenna Module																																																											
D	2005	(DW)STS	Body	Vehicle Comm. Interface Module																																																											
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DM)CTS	Chassis	Tire Pressure Monitor																																																											
D	2006	(DM)CTS	Chassis	VES																																																											
D	2006	(DM)CTS	Body	Amplifier (Bose)																																																											
D	2006	(DM)CTS	Body	Amplifier (Delco)																																																											
D	2006	(DM)CTS	Body	Climate Control Panel																																																											
D	2006	(DM)CTS	Body	Dash Integration Module																																																											
D	2006	(DM)CTS	Body	Digital Radio Receiver																																																											
D	2006	(DM)CTS	Body	Driver Door Switch																																																											
D	2006	(DM)CTS	Body	Driver Door Module																																																											
D	2006	(DM)CTS	Body	Passenger Door Module																																																											
D	2006	(DM)CTS	Body	Left Rear Door Module																																																											
D	2006	(DM)CTS	Body	Right Rear Door Module																																																											
D	2006	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DM)CTS	Body	Instrument Panel Cluster																																																											
D	2006	(DM)CTS	Body	Memory Seat Module																																																											
D	2006	(DM)CTS	Body	Personalization																																																											
D	2006	(DM)CTS	Body	Radio																																																											
D	2006	(DM)CTS	Body	Rear Integration Module																																																											
D	2006	(DM)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DM)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DM)CTS	Body	TV Antenna Module																																																											
D	2006	(DM)CTS	Body	Vehicle Theft Deterrent																																																											
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DP)CTS	Chassis	Tire Pressure Monitor																																																											
D	2006	(DP)CTS	Chassis	VES																																																											
D	2006	(DP)CTS	Body	Amplifier (Bose)																																																											
D	2006	(DP)CTS	Body	Amplifier (Delco)																																																											
D	2006	(DP)CTS	Body	Climate Control Panel																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2006	(DP)CTS	Body	Dash Integration Module																																																										
D	2006	(DP)CTS	Body	Digital Radio Receiver																																																											
D	2006	(DP)CTS	Body	Driver Door Switch																																																											
D	2006	(DP)CTS	Body	Driver Door Module																																																											
D	2006	(DP)CTS	Body	Passenger Door Module																																																											
D	2006	(DP)CTS	Body	Left Rear Door Module																																																											
D	2006	(DP)CTS	Body	Right Rear Door Module																																																											
D	2006	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DP)CTS	Body	Instrument Panel Cluster																																																											
D	2006	(DP)CTS	Body	Memory Seat Module																																																											
D	2006	(DP)CTS	Body	Personalization																																																											
D	2006	(DP)CTS	Body	Radio																																																											
D	2006	(DP)CTS	Body	Rear Integration Module																																																											
D	2006	(DP)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DP)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DP)CTS	Body	TV Antenna Module																																																											
D	2006	(DP)CTS	Body	Vehicle Theft Deterrent																																																											
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DR)CTS	Chassis	Tire Pressure Monitor																																																											
D	2006	(DR)CTS	Chassis	VES																																																											
D	2006	(DR)CTS	Body	Amplifier (Bose)																																																											
D	2006	(DR)CTS	Body	Amplifier (Delco)																																																											
D	2006	(DR)CTS	Body	Climate Control Panel																																																											
D	2006	(DR)CTS	Body	Dash Integration Module																																																											
D	2006	(DR)CTS	Body	Digital Radio Receiver																																																											
D	2006	(DR)CTS	Body	Driver Door Switch																																																											
D	2006	(DR)CTS	Body	Driver Door Module																																																											
D	2006	(DR)CTS	Body	Passenger Door Module																																																											
D	2006	(DR)CTS	Body	Left Rear Door Module																																																											
D	2006	(DR)CTS	Body	Right Rear Door Module																																																											
D	2006	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DR)CTS	Body	Instrument Panel Cluster																																																											
D	2006	(DR)CTS	Body	Memory Seat Module																																																											
D	2006	(DR)CTS	Body	Personalization																																																											
D	2006	(DR)CTS	Body	Radio																																																											
D	2006	(DR)CTS	Body	Rear Integration Module																																																											
D	2006	(DR)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DR)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DR)CTS	Body	TV Antenna Module																																																											
D	2006	(DR)CTS	Body	Vehicle Theft Deterrent																																																											
D	2006	(DN)CTS-V	Powertrain	Engine Control Module																																																											
D	2006	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																											
D	2006	(DN)CTS-V	Chassis	VES																																																											
D	2006	(DN)CTS-V	Body	Amplifier (Bose)																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2006	(DN)CTS-V	Body	Amplifier (Delco)																																																											
D	2006	(DN)CTS-V	Body	Climate Control Panel																																																												
D	2006	(DN)CTS-V	Body	Dash Integration Module																																																												
D	2006	(DN)CTS-V	Body	Digital Radio Receiver																																																												
D	2006	(DN)CTS-V	Body	Driver Door Switch																																																												
D	2006	(DN)CTS-V	Body	Driver Door Module																																																												
D	2006	(DN)CTS-V	Body	Passenger Door Module																																																												
D	2006	(DN)CTS-V	Body	Left Rear Door Module																																																												
D	2006	(DN)CTS-V	Body	Right Rear Door Module																																																												
D	2006	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																												
D	2006	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																												
D	2006	(DN)CTS-V	Body	Instrument Panel Cluster																																																												
D	2006	(DN)CTS-V	Body	Memory Seat Module																																																												
D	2006	(DN)CTS-V	Body	Personalization																																																												
D	2006	(DN)CTS-V	Body	Rear Integration Module																																																												
D	2006	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																												
D	2006	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																												
D	2006	(DN)CTS-V	Body	TV Antenna Module																																																												
D	2006	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																												
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Engine Controls																																																												
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
D	2006	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																												
D	2006	(DC)STS-V8	Chassis	Electronic Suspension Control																																																												
D	2006	(DC)STS-V8	Body	Amplifier (Bose)																																																												
D	2006	(DC)STS-V8	Body	Digital Radio Receiver																																																												
D	2006	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																												
D	2006	(DC)STS-V8	Body	Driver Door Module																																																												
D	2006	(DC)STS-V8	Body	Driver Door Switch																																																												
D	2006	(DC)STS-V8	Body	Driver Position Module																																																												
D	2006	(DC)STS-V8	Body	Headlamp Control Module																																																												
D	2006	(DC)STS-V8	Body	Head Up Display																																																												
D	2006	(DC)STS-V8	Body	HVAC Control Module																																																												
D	2006	(DC)STS-V8	Body	Instrument Panel Cluster																																																												
D	2006	(DC)STS-V8	Body	Instrument Panel Module																																																												
D	2006	(DC)STS-V8	Body	Left Rear Door Module																																																												
D	2006	(DC)STS-V8	Body	Passenger Door Module																																																												
D	2006	(DC)STS-V8	Body	Uplevel Radio																																																												
D	2006	(DC)STS-V8	Body	Navigation Radio																																																												
D	2006	(DC)STS-V8	Body	Rear Integration Module																																																												
D	2006	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																												
D	2006	(DC)STS-V8	Body	Right Rear Door Module																																																												
D	2006	(DC)STS-V8	Body	Steering Column Lock Module																																																												
D	2006	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																												
D	2006	(DC)STS-V8	Body	TV Antenna Module																																																												
D	2006	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																												
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2006	(DW)STS	Chassis	Electronic Brake Control Module																																																												
D	2006	(DW)STS	Chassis	Electronic Suspension Control																																																												
D	2006	(DW)STS	Body	Amplifier (Bose)																																																												
D	2006	(DW)STS	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2006	(DW)STS	Body	Distance Sensing Cruise Control																																																										
D	2006	(DW)STS	Body	Driver Door Module																																																											
D	2006	(DW)STS	Body	Driver Door Switch																																																											
D	2006	(DW)STS	Body	Driver Position Module																																																											
D	2006	(DW)STS	Body	Headlamp Control Module																																																											
D	2006	(DW)STS	Body	Head Up Display																																																											
D	2006	(DW)STS	Body	HVAC Control Module																																																											
D	2006	(DW)STS	Body	Instrument Panel Cluster																																																											
D	2006	(DW)STS	Body	Instrument Panel Module																																																											
D	2006	(DW)STS	Body	Left Rear Door Module																																																											
D	2006	(DW)STS	Body	Passenger Door Module																																																											
D	2006	(DW)STS	Body	Uplevel Radio																																																											
D	2006	(DW)STS	Body	Navigation Radio																																																											
D	2006	(DW)STS	Body	Rear Integration Module																																																											
D	2006	(DW)STS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DW)STS	Body	Right Rear Door Module																																																											
D	2006	(DW)STS	Body	Steering Column Lock Module																																																											
D	2006	(DW)STS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DW)STS	Body	TV Antenna Module																																																											
D	2006	(DW)STS	Body	Vehicle Comm. Interface Module																																																											
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Engine Control Module	V																																																										
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Transmission Control Module		V	V																																																								
D	2006	(DX)STS-V	Chassis	Electronic Brake Control Module																																																											
D	2006	(DX)STS-V	Chassis	Electronic Suspension Control																																																											
D	2006	(DX)STS-V	Body	Amplifier (Bose)																																																											
D	2006	(DX)STS-V	Body	Digital Radio Receiver																																																											
D	2006	(DX)STS-V	Body	Distance Sensing Cruise Control																																																											
D	2006	(DX)STS-V	Body	Driver Door Module																																																											
D	2006	(DX)STS-V	Body	Driver Door Switch																																																											
D	2006	(DX)STS-V	Body	Driver Position Module																																																											
D	2006	(DX)STS-V	Body	Headlamp Control Module																																																											
D	2006	(DX)STS-V	Body	Head Up Display																																																											
D	2006	(DX)STS-V	Body	HVAC Control Module																																																											
D	2006	(DX)STS-V	Body	Instrument Panel Cluster																																																											
D	2006	(DX)STS-V	Body	Instrument Panel Module																																																											
D	2006	(DX)STS-V	Body	Left Rear Door Module																																																											
D	2006	(DX)STS-V	Body	Passenger Door Module																																																											
D	2006	(DX)STS-V	Body	Uplevel Radio																																																											
D	2006	(DX)STS-V	Body	Navigation Radio																																																											
D	2006	(DX)STS-V	Body	Rear Integration Module																																																											
D	2006	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DX)STS-V	Body	Right Rear Door Module																																																											
D	2006	(DX)STS-V	Body	Steering Column Lock Module																																																											
D	2006	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DX)STS-V	Body	TV Antenna Module																																																											
D	2006	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																											
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto				V																																																							
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual				V																																																							
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto				V																																																							
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual				V																																																							

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2007	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2007	(DM)CTS	Chassis	VES																																																										
D	2007	(DM)CTS	Body	Amplifier (Bose)																																																										
D	2007	(DM)CTS	Body	Amplifier (Delco)																																																										
D	2007	(DM)CTS	Body	Climate Control Panel																																																										
D	2007	(DM)CTS	Body	Dash Integration Module																																																										
D	2007	(DM)CTS	Body	Digital Radio Receiver																																																										
D	2007	(DM)CTS	Body	Driver Door Switch																																																										
D	2007	(DM)CTS	Body	Driver Door Module																																																										
D	2007	(DM)CTS	Body	Passenger Door Module																																																										
D	2007	(DM)CTS	Body	Left Rear Door Module																																																										
D	2007	(DM)CTS	Body	Right Rear Door Module																																																										
D	2007	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2007	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2007	(DM)CTS	Body	Instrument Panel Cluster																																																										
D	2007	(DM)CTS	Body	Memory Seat Module																																																										
D	2007	(DM)CTS	Body	Personalization																																																										
D	2007	(DM)CTS	Body	Rear Integration Module																																																										
D	2007	(DM)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2007	(DM)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DM)CTS	Body	Theft Deterrent Module																																																										
D	2007	(DM)CTS	Body	TV Antenna Module																																																										
D	2007	(DM)CTS	Body	Vehicle Comm. Interface Module																																																										
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto				V																																																					
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual				V																																																					
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto				V																																																					
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual				V																																																					
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2007	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2007	(DP)CTS	Chassis	VES																																																										
D	2007	(DP)CTS	Body	Amplifier (Bose)																																																										
D	2007	(DP)CTS	Body	Amplifier (Delco)																																																										
D	2007	(DP)CTS	Body	Climate Control Panel																																																										
D	2007	(DP)CTS	Body	Dash Integration Module																																																										
D	2007	(DP)CTS	Body	Digital Radio Receiver																																																										
D	2007	(DP)CTS	Body	Driver Door Switch																																																										
D	2007	(DP)CTS	Body	Driver Door Module																																																										
D	2007	(DP)CTS	Body	Passenger Door Module																																																										
D	2007	(DP)CTS	Body	Left Rear Door Module																																																										
D	2007	(DP)CTS	Body	Right Rear Door Module																																																										
D	2007	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2007	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2007	(DP)CTS	Body	Instrument Panel Cluster																																																										
D	2007	(DP)CTS	Body	Memory Seat Module																																																										
D	2007	(DP)CTS	Body	Personalization																																																										
D	2007	(DP)CTS	Body	Rear Integration Module																																																										
D	2007	(DP)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2007	(DP)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DP)CTS	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2007	(DP)CTS	Body	TV Antenna Module																																																											
D	2007	(DP)CTS	Body	Vehicle Comm. Interface Module																																																											
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto				V																																																							
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual				V																																																							
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto				V																																																							
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual				V																																																							
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2007	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2007	(DR)CTS	Chassis	VES																																																											
D	2007	(DR)CTS	Body	Amplifier (Bose)																																																											
D	2007	(DR)CTS	Body	Amplifier (Delco)																																																											
D	2007	(DR)CTS	Body	Climate Control Panel																																																											
D	2007	(DR)CTS	Body	Dash Integration Module																																																											
D	2007	(DR)CTS	Body	Digital Radio Receiver																																																											
D	2007	(DR)CTS	Body	Driver Door Switch																																																											
D	2007	(DR)CTS	Body	Driver Door Module																																																											
D	2007	(DR)CTS	Body	Passenger Door Module																																																											
D	2007	(DR)CTS	Body	Left Rear Door Module																																																											
D	2007	(DR)CTS	Body	Right Rear Door Module																																																											
D	2007	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2007	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2007	(DR)CTS	Body	Instrument Panel Cluster																																																											
D	2007	(DR)CTS	Body	Memory Seat Module																																																											
D	2007	(DR)CTS	Body	Personalization																																																											
D	2007	(DR)CTS	Body	Rear Integration Module																																																											
D	2007	(DR)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2007	(DR)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2007	(DR)CTS	Body	Theft Deterrent Module																																																											
D	2007	(DR)CTS	Body	TV Antenna Module																																																											
D	2007	(DR)CTS	Body	Vehicle Comm. Interface Module																																																											
D	2007	(DN)CTS-V	Powertrain	(U)6.0L V8 LS2 Engine Control Module	V																																																										
D	2007	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																											
D	2007	(DN)CTS-V	Chassis	VES																																																											
D	2007	(DN)CTS-V	Body	Amplifier (Bose)																																																											
D	2007	(DN)CTS-V	Body	Amplifier (Delco)																																																											
D	2007	(DN)CTS-V	Body	Climate Control Panel																																																											
D	2007	(DN)CTS-V	Body	Dash Integration Module																																																											
D	2007	(DN)CTS-V	Body	Digital Radio Receiver																																																											
D	2007	(DN)CTS-V	Body	Driver Door Switch																																																											
D	2007	(DN)CTS-V	Body	Driver Door Module																																																											
D	2007	(DN)CTS-V	Body	Passenger Door Module																																																											
D	2007	(DN)CTS-V	Body	Left Rear Door Module																																																											
D	2007	(DN)CTS-V	Body	Right Rear Door Module																																																											
D	2007	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																											
D	2007	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																											
D	2007	(DN)CTS-V	Body	Instrument Panel Cluster																																																											
D	2007	(DN)CTS-V	Body	Memory Seat Module																																																											
D	2007	(DN)CTS-V	Body	Personalization																																																											
D	2007	(DN)CTS-V	Body	Rear Integration Module																																																											
D	2007	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2007	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																											
D	2007	(DN)CTS-V	Body	Theft Deterrent Module																																																											
D	2007	(DN)CTS-V	Body	TV Antenna Module																																																											
D	2007	(DN)CTS-V	Body	Vehicle Comm. Interface Module																																																											
D	2007	(DC)STS-V8	Powertrain	Engine Control Module	V				V																																																						
D	2007	(DC)STS-V8	Powertrain	Transmission Control Module		V																																																									
D	2007	(DC)STS-V8	Chassis	Electronic Brake Control Module						V																																																					
D	2007	(DC)STS-V8	Chassis	Electronic Suspension Control																																																											
D	2007	(DC)STS-V8	Body	Amplifier (Bose)																																																											
D	2007	(DC)STS-V8	Body	Digital Radio Receiver																																																											
D	2007	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																											
D	2007	(DC)STS-V8	Body	Driver Door Module																																																											
D	2007	(DC)STS-V8	Body	Driver Door Switch																																																											
D	2007	(DC)STS-V8	Body	Driver Position Module																																																											
D	2007	(DC)STS-V8	Body	Headlamp Control Module																																																											
D	2007	(DC)STS-V8	Body	Head Up Display																																																											
D	2007	(DC)STS-V8	Body	HVAC Control Module																																																											
D	2007	(DC)STS-V8	Body	Instrument Panel Cluster																																																											
D	2007	(DC)STS-V8	Body	Instrument Panel Module							V																																																				
D	2007	(DC)STS-V8	Body	Left Rear Door Module																																																											
D	2007	(DC)STS-V8	Body	Passenger Door Module																																																											
D	2007	(DC)STS-V8	Body	Uplevel Radio								V																																																		
D	2007	(DC)STS-V8	Body	Navigation Radio																																																											
D	2007	(DC)STS-V8	Body	Rear Integration Module																																																											
D	2007	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																											
D	2007	(DC)STS-V8	Body	Right Rear Door Module																																																											
D	2007	(DC)STS-V8	Body	Steering Column Lock Module																																																											
D	2007	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																											
D	2007	(DC)STS-V8	Body	TV Antenna Module																																																											
D	2007	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																											
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module				V																																																							
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2007	(DW)STS	Chassis	Electronic Brake Control Module						V																																																					
D	2007	(DW)STS	Chassis	Electronic Suspension Control																																																											
D	2007	(DW)STS	Body	Amplifier (Bose)																																																											
D	2007	(DW)STS	Body	Digital Radio Receiver																																																											
D	2007	(DW)STS	Body	Distance Sensing Cruise Control																																																											
D	2007	(DW)STS	Body	Driver Door Module																																																											
D	2007	(DW)STS	Body	Driver Door Switch																																																											
D	2007	(DW)STS	Body	Driver Position Module																																																											
D	2007	(DW)STS	Body	Headlamp Control Module																																																											
D	2007	(DW)STS	Body	Head Up Display																																																											
D	2007	(DW)STS	Body	HVAC Control Module																																																											
D	2007	(DW)STS	Body	Instrument Panel Cluster																																																											
D	2007	(DW)STS	Body	Instrument Panel Module							V																																																				
D	2007	(DW)STS	Body	Left Rear Door Module																																																											
D	2007	(DW)STS	Body	Passenger Door Module																																																											
D	2007	(DW)STS	Body	Uplevel Radio								V																																																		
D	2007	(DW)STS	Body	Navigation Radio																																																											
D	2007	(DW)STS	Body	Rear Integration Module																																																											
D	2007	(DW)STS	Body	Remote Control Door Lock Receiver																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2007	(DW)STS	Body	Right Rear Door Module																																																											
D	2007	(DW)STS	Body	Steering Column Lock Module																																																											
D	2007	(DW)STS	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DW)STS	Body	TV Antenna Module																																																										
D	2007	(DW)STS	Body	Vehicle Comm. Interface Module																																																										
D	2007	(DX)STS-V	Powertrain	Engine Control Module	V				V																																																					
D	2007	(DX)STS-V	Powertrain	Transmission Control Module		V																																																								
D	2007	(DX)STS-V	Chassis	Electronic Brake Control Module						V																																																				
D	2007	(DX)STS-V	Chassis	Electronic Suspension Control																																																										
D	2007	(DX)STS-V	Body	Amplifier (Bose)																																																										
D	2007	(DX)STS-V	Body	Digital Radio Receiver																																																										
D	2007	(DX)STS-V	Body	Distance Sensing Cruise Control																																																										
D	2007	(DX)STS-V	Body	Driver Door Module																																																										
D	2007	(DX)STS-V	Body	Driver Door Switch																																																										
D	2007	(DX)STS-V	Body	Driver Position Module																																																										
D	2007	(DX)STS-V	Body	Headlamp Control Module																																																										
D	2007	(DX)STS-V	Body	Head Up Display																																																										
D	2007	(DX)STS-V	Body	HVAC Control Module																																																										
D	2007	(DX)STS-V	Body	Instrument Panel Cluster																																																										
D	2007	(DX)STS-V	Body	Instrument Panel Module							V																																																			
D	2007	(DX)STS-V	Body	Left Rear Door Module																																																										
D	2007	(DX)STS-V	Body	Passenger Door Module																																																										
D	2007	(DX)STS-V	Body	Uplevel Radio								V																																																	
D	2007	(DX)STS-V	Body	Navigation Radio																																																										
D	2007	(DX)STS-V	Body	Rear Integration Module																																																										
D	2007	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																										
D	2007	(DX)STS-V	Body	Right Rear Door Module																																																										
D	2007	(DX)STS-V	Body	Steering Column Lock Module																																																										
D	2007	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DX)STS-V	Body	TV Antenna Module																																																										
D	2007	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																										
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module				V					V																																																	
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module		V																																																								
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module				V						V																																																
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module		V																																																								
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module											V	V																																														
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module				V					V																																																		
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module		V																																																									
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module											V	V																																														
D	2008	CTS	Chassis	Electronic Brake Control Module						V							V	V																																													
D	2008	CTS	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V																																		
D	2008	CTS	Body	Body Control Module (aux.)																																																										
D	2008	CTS	Body	Driver Door Switch																																																										
D	2008	CTS	Body	Headlamp Control Module																								V	V	V																																
D	2008	CTS	Body	HVAC Control Module																											V	V	V																												
D	2008	CTS	Body	Infotainment Faceplate Module																																																										
D	2008	CTS	Body	Instrument Panel Cluster																																																										
D	2008	CTS	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																			
D	2008	CTS	Body	Park Assist Module																																							V	V	V																
D	2008	CTS	Body	Passenger Door Switch																																																										
D	2008	CTS	Body	Passenger Presence System																																										V	V															

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2008	CTS	Body	Pedestrian Impact Detection Module																																												V	V	V	V								
D	2008	CTS	Body	Radio																																															V	V	V					
D	2008	CTS	Body	Supplemental Inflatable Restraint																																									V									V				
D	2008	CTS	Body	TV Antenna Module																																																						
D	2008	CTS	Body	Vehicle Comm. Interface Module																																																						
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																						
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																						
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																						
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																						
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V				V																																																		
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module		V																																																					
D	2008	SLS	Chassis	Electronic Brake Control Module						V																																																	
D	2008	SLS	Chassis	Electronic Suspension Control																																																							
D	2008	SLS	Body	Amplifier (Bose)																																																						
D	2008	SLS	Body	Driver Door Module																																																						
D	2008	SLS	Body	Driver Door Switch																																																						
D	2008	SLS	Body	Driver Position Module																																																						
D	2008	SLS	Body	Headlamp Control Module																																																						
D	2008	SLS	Body	HVAC Control Module																																																						
D	2008	SLS	Body	Instrument Panel Cluster																																																		V				
D	2008	SLS	Body	Instrument Panel Module							V																																															
D	2008	SLS	Body	Left Rear Door Module																																																						
D	2008	SLS	Body	Passenger Door Module																																																						
D	2008	SLS	Body	Radio																																																			V			
D	2008	SLS	Body	Rear HVAC/RSA																																																						
D	2008	SLS	Body	Rear Integration Module																																																						
D	2008	SLS	Body	Remote Control Door Lock Receiver																																																						
D	2008	SLS	Body	Right Rear Door Module																																																						
D	2008	SLS	Body	Supplemental Inflatable Restraint																																																						
D	2008	SLS	Body	TV Antenna Module																																																						
D	2008	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module				V					V																																														
D	2008	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module		V																																																					
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module	V																																																						
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module		V																																																					
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V																																																						
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module		V																																																					
D	2008	STS	Chassis	Electronic Brake Control Module With (RPO JL7)						V																																																	
D	2008	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																							
D	2008	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																					V	V
D	2008	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																						
D	2008	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)						V																																																
D	2008	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																						
D	2008	STS	Body	Amplifier (Bose)																																																						
D	2008	STS	Body	Digital Radio Receiver																																																						
D	2008	STS	Body	Distance Sensing Cruise Control																																																						
D	2008	STS	Body	Driver Door Module																																																						
D	2008	STS	Body	Driver Door Switch																																																						
D	2008	STS	Body	Driver Position Module																																																						
D	2008	STS	Body	Headlamp Control Module																																																						
D	2008	STS	Body	Head Up Display																																																						
D	2008	STS	Body	HVAC Control Module																																																						

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2008	STS	Body	Instrument Panel Cluster																																																											
D	2008	STS	Body	Instrument Panel Module							V																																																				
D	2008	STS	Body	Left Rear Door Module																																																											
D	2008	STS	Body	Left Side Object Detection Module																																							V				V																
D	2008	STS	Body	Passenger Door Module																																																										
D	2008	STS	Body	Uplevel Radio								V																																																		
D	2008	STS	Body	Navigation Radio																																																										
D	2008	STS	Body	Rear Integration Module																																																										
D	2008	STS	Body	Remote Control Door Lock Receiver																																																										
D	2008	STS	Body	Right Rear Door Module																																																										
D	2008	STS	Body	Right Side Object Detection Module																																							V				V																
D	2008	STS	Body	Steering Column Lock Module																																																										
D	2008	STS	Body	Supplemental Inflatable Restraint																																																										
D	2008	STS	Body	TV Antenna Module																																																										
D	2008	STS	Body	Vehicle Comm. Interface Module																																																										
D	2008	STS	Body	Veh Direction Alert Alarm Warn Mod																																							V																			
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto	V			V																																																						
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual	V			V																																																						
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module		V																																																								
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module				V					V																																																	
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module		V																																																								
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module				V						V																																																
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module		V																																																								
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module											V	V																																														
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module				V					V																																																		
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module		V																																																									
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module											V	V																																															
D	2009	CTS	Chassis	Electronic Brake Control Module						V							V	V																																													
D	2009	CTS	Chassis	Electronic Suspension Control																																																												
D	2009	CTS	Chassis	Parking Brake Control Module																																																											
D	2009	CTS	Body	Body Control Module															V	V		V	V		V		V	V																																			
D	2009	CTS	Body	Body Control Module (aux.)																																																											
D	2009	CTS	Body	Driver Door Switch																																																											
D	2009	CTS	Body	Headlamp Control Module																								V	V	V																																	
D	2009	CTS	Body	HVAC Control Module																											V	V	V																														
D	2009	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																											
D	2009	CTS	Body	Instrument Panel Cluster (Other)																																																											
D	2009	CTS	Body	Memory Seat Module																													V	V	V	V	V	V	V	V	V																					
D	2009	CTS	Body	Park Assist Module																																						V	V	V																		
D	2009	CTS	Body	Passenger Door Switch																																																										
D	2009	CTS	Body	Passenger Presence System																																									V																	
D	2009	CTS	Body	Pedestrian Impact Detection Module																																											V	V	V	V											
D	2009	CTS	Body	Radio																																															V	V	V							
D	2009	CTS	Body	Supplemental Inflatable Restraint																																									V									V					
D	2009	CTS	Body	TV Antenna Module																																																									
D	2009	CTS	Body	Vehicle Comm. Interface Module																																																										
D	2009	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2009	SLS	Powertrain	(T)2.8L V6 LP2 Transmission Control Module																																																										
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V				V																																																						
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module		V																																																									
D	2009	SLS	Chassis	Electronic Brake Control Module						V																																																					
D	2009	SLS	Chassis	Electronic Suspension Control																																																											
D	2009	SLS	Body	Amplifier (Bose)																																																											
D	2009	SLS	Body	Driver Door Module																																																										
D	2009	SLS	Body	Driver Door Switch																																																										
D	2009	SLS	Body	Driver Position Module																																																										
D	2009	SLS	Body	Headlamp Control Module																																																										
D	2009	SLS	Body	HVAC Control Module																																																										
D	2009	SLS	Body	Instrument Panel Cluster																																																			V			
D	2009	SLS	Body	Instrument Panel Module							V																																																		
D	2009	SLS	Body	Left Rear Door Module																																																										
D	2009	SLS	Body	Passenger Door Module																																																										
D	2009	SLS	Body	Radio																																																					V			
D	2009	SLS	Body	Rear HVAC/RSA																																																										
D	2009	SLS	Body	Rear Integration Module																																																										
D	2009	SLS	Body	Remote Control Door Lock Receiver																																																										
D	2009	SLS	Body	Right Rear Door Module																																																										
D	2009	SLS	Body	Supplemental Inflatable Restraint																																																										
D	2009	SLS	Body	TV Antenna Module																																																										
D	2009	SLS	Body	Vehicle Comm. Interface Module																																																										
D	2009	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module				V						V																																																
D	2009	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module		V																																																								
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module	V																																																									
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module		V																																																								
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V																																																									
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module		V																																																								
D	2009	STS	Chassis	Electronic Brake Control Module With (RPO JL7)						V																																																				
D	2009	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																										
D	2009	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																							V	V
D	2009	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																									
D	2009	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)						V							V	V																																											
D	2009	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																										
D	2009	STS	Body	Amplifier (Bose)																																																										
D	2009	STS	Body	Digital Radio Receiver																																																										
D	2009	STS	Body	Distance Sensing Cruise Control																																																										
D	2009	STS	Body	Driver Door Module																																																										
D	2009	STS	Body	Driver Door Switch																																																										
D	2009	STS	Body	Driver Position Module																																																										
D	2009	STS	Body	Headlamp Control Module																																																										
D	2009	STS	Body	Head Up Display																																																										
D	2009	STS	Body	HVAC Control Module																																																										
D	2009	STS	Body	Instrument Panel Cluster																																																						V			
D	2009	STS	Body	Instrument Panel Module							V																																																		
D	2009	STS	Body	Left Rear Door Module																																																										
D	2009	STS	Body	Left Side Object Detection Module																																								V					V													
D	2009	STS	Body	Passenger Door Module																																																										
D	2009	STS	Body	Uplevel Radio								V																																																	
D	2009	STS	Body	Navigation Radio																																																										
D	2009	STS	Body	Rear Integration Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2009	STS	Body	Remote Control Door Lock Receiver																																																										
D	2009	STS	Body	Right Rear Door Module																																																										
D	2009	STS	Body	Right Side Object Detection Module																																								V					V													
D	2009	STS	Body	Steering Column Lock Module																																																									
D	2009	STS	Body	Supplemental Inflatable Restraint																																																										
D	2009	STS	Body	TV Antenna Module																																																									
D	2009	STS	Body	Vehicle Comm. Interface Module																																																										
D	2009	STS	Body	Veh Direction Alert Alarm Warn Mod																																								V																			
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto	V			V																																																						
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual	V			V																																																						
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module		V																																																								
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Auto	V			V																																																						
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Manual	V			V																																																						
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transmission Control Module		V																																																								
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transfer Case Control Module											V	V																																														
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module Auto																																																											
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module		V																																																								
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module											V	V																																														
D	2010	CTS	Chassis	Electronic Brake Control Module						V							V	V																																													
D	2010	CTS	Chassis	Electronic Suspension Control																																																											
D	2010	CTS	Chassis	Parking Brake Control Module																																																										
D	2010	CTS	Body	Body Control Module															V	V		V	V		V		V	V																																		
D	2010	CTS	Body	Body Control Module (aux.)																																																										
D	2010	CTS	Body	Driver Door Switch																																																										
D	2010	CTS	Body	Headlamp Control Module																									V	V	V																																
D	2010	CTS	Body	HVAC Control Module																												V	V	V																												
D	2010	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																										
D	2010	CTS	Body	Instrument Panel Cluster (Other)																																																										
D	2010	CTS	Body	Liftgate Module																																																										
D	2010	CTS	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				
D	2010	CTS	Body	Park Assist Module																																							V	V	V																	
D	2010	CTS	Body	Passenger Door Switch																																																										
D	2010	CTS	Body	Passenger Presence System																																										V																
D	2010	CTS	Body	Pedestrian Impact Detection Module																																												V	V	V	V										
D	2010	CTS	Body	Radio																																															V	V	V							
D	2010	CTS	Body	Supplemental Inflatable Restraint																																																										
D	2010	CTS	Body	TV Antenna Module																																																										
D	2010	CTS	Body	Vehicle Comm. Interface Module																																																										
D	2010	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																										
D	2010	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module		V																																																								
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V																																																									
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module		V																																																								
D	2010	STS	Chassis	Electronic Brake Control Module With (RPO JL7)						V																																																				
D	2010	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																										
D	2010	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																								V	V
D	2010	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)						V							V	V																																												
D	2010	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2010	STS	Body	Amplifier (Bose)																																																											
D	2010	STS	Body	Digital Radio Receiver																																																											
D	2010	STS	Body	Distance Sensing Cruise Control																																																											
D	2010	STS	Body	Driver Door Module																																																											
D	2010	STS	Body	Driver Door Switch																																																											
D	2010	STS	Body	Driver Position Module																																																											
D	2010	STS	Body	Headlamp Control Module																																																											
D	2010	STS	Body	Head Up Display																																																											
D	2010	STS	Body	HVAC Control Module																																																											
D	2010	STS	Body	Instrument Panel Cluster																																																											
D	2010	STS	Body	Instrument Panel Module							V																																																				
D	2010	STS	Body	Left Rear Door Module																																																											
D	2010	STS	Body	Left Side Object Detection Module																																								V				V															
D	2010	STS	Body	Passenger Door Module																																																											
D	2010	STS	Body	Uplevel Radio								V																																																			
D	2010	STS	Body	Navigation Radio																																																											
D	2010	STS	Body	Rear Integration Module																																																											
D	2010	STS	Body	Remote Control Door Lock Receiver																																																											
D	2010	STS	Body	Right Rear Door Module																																																											
D	2010	STS	Body	Right Side Object Detection Module																																								V				V															
D	2010	STS	Body	Steering Column Lock Module																																																											
D	2010	STS	Body	Supplemental Inflatable Restraint																																																											
D	2010	STS	Body	TV Antenna Module																																																											
D	2010	STS	Body	Vehicle Comm. Interface Module																																																											
D	2010	STS	Body	Veh Direction Alert Alarm Warn Mod																																								V																			
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto	V			V																																																							
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual	V			V																																																							
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																											
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module		V																																																									
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Auto	V			V																																																							
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Manual	V			V																																																							
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module		V																																																									
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																											
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transfer Case Control Module											V	V																																															
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																											
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transmission Control Module		V																																																									
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Fuel Pump Control Module																																																											
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transfer Case Control Module											V	V																																															
D	2011	CTS	Chassis	Electronic Brake Control Module						V							V	V																																													
D	2011	CTS	Chassis	Electronic Suspension Control																																																											
D	2011	CTS	Chassis	Parking Brake Control Module																																																											
D	2011	CTS	Body	Body Control Module (6.2L V8 LSA)														V	V		V	V		V		V	V																																				
D	2011	CTS	Body	Body Control Module (Other)														V	V		V	V		V		V	V																																				
D	2011	CTS	Body	Body Control Module (aux.)																																																											
D	2011	CTS	Body	Driver Door Switch																																																											
D	2011	CTS	Body	Headlamp Control Module																									V	V	V																																
D	2011	CTS	Body	HVAC Control Module																												V	V	V																													
D	2011	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																											
D	2011	CTS	Body	Instrument Panel Cluster (Other)																																																											
D	2011	CTS	Body	Liftgate Module																																																											
D	2011	CTS	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2011	CTS	Body	Park Assist Module																																								V	V	V															
D	2011	CTS	Body	Passenger Door Switch																																																								
D	2011	CTS	Body	Passenger Presence System																																										V														
D	2011	CTS	Body	Pedestrian Impact Detection Module																																											V	V	V	V										
D	2011	CTS	Body	Radio																																														V	V	V						
D	2011	CTS	Body	Supplemental Inflatable Restraint																																																							
D	2011	CTS	Body	TV Antenna Module																																																							
D	2011	CTS	Body	Vehicle Comm. Interface Module																																																							
D	2011	STS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																							
D	2011	STS	Powertrain	(D)3.6L V6 LLT Transmission Control Module		V																																																					
D	2011	STS	Chassis	Electronic Brake Control Module						V							V	V																																										
D	2011	STS	Chassis	Electronic Suspension Control																																																							
D	2011	STS	Body	Amplifier (Bose)																																																						
D	2011	STS	Body	Digital Radio Receiver																																																						
D	2011	STS	Body	Distance Sensing Cruise Control																																																						
D	2011	STS	Body	Driver Door Module																																																						
D	2011	STS	Body	Driver Door Switch																																																						
D	2011	STS	Body	Driver Position Module																																																						
D	2011	STS	Body	Headlamp Control Module																																																						
D	2011	STS	Body	Head Up Display																																																						
D	2011	STS	Body	HVAC Control Module																																																						
D	2011	STS	Body	Instrument Panel Cluster																																																		V				
D	2011	STS	Body	Instrument Panel Module							V																																															
D	2011	STS	Body	Left Rear Door Module																																																						
D	2011	STS	Body	Left Side Object Detection Module																																							V				V												
D	2011	STS	Body	Passenger Door Module																																																						
D	2011	STS	Body	Uplevel Radio								V																																														
D	2011	STS	Body	Navigation Radio																																																						
D	2011	STS	Body	Rear Integration Module																																																						
D	2011	STS	Body	Remote Control Door Lock Receiver																																																						
D	2011	STS	Body	Right Rear Door Module																																																						
D	2011	STS	Body	Right Side Object Detection Module																																							V				V												
D	2011	STS	Body	Supplemental Inflatable Restraint																																																						
D	2011	STS	Body	TV Antenna Module																																																						
D	2011	STS	Body	Vehicle Comm. Interface Module																																																						
D	2011	STS	Body	Veh Direction Alert Alarm Warn Mod																																							V																
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto	V			V																																																			
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual	V			V																																																			
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																						
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module		V																																																				
D	2012	P Type Engine	Chassis	Electronic Brake Control Module						V							V	V																																									
D	2012	P Type Engine	Chassis	Electronic Suspension Control																																																						
D	2012	P Type Engine	Chassis	Parking Brake Control Module																																																					
D	2012	P Type Engine	Body	Body Control Module															V	V		V	V		V		V	V																														
D	2012	P Type Engine	Body	Body Control Module (aux.)																																																					
D	2012	P Type Engine	Body	Driver Door Switch																																																					
D	2012	P Type Engine	Body	Headlamp Control Module																								V	V	V																												
D	2012	P Type Engine	Body	HVAC Control Module																											V	V	V																								
D	2012	P Type Engine	Body	Instrument Panel Cluster																																																					
D	2012	P Type Engine	Body	Left Side Object Detection Module																																							V				V											
D	2012	P Type Engine	Body	Liftgate Module																																																					

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2012	P Type Engine	Body	Memory Seat Module																															V	V	V	V	V	V	V	V	V																			
D	2012	P Type Engine	Body	Park Assist Module																																								V	V	V															
D	2012	P Type Engine	Body	Passenger Door Switch																																																									
D	2012	P Type Engine	Body	Passenger Presence System																																											V															
D	2012	P Type Engine	Body	Pedestrian Impact Detection Module																																													V	V	V	V										
D	2012	P Type Engine	Body	Radio																																																V	V	V							
D	2012	P Type Engine	Body	Right Side Object Detection Module																																								V					V													
D	2012	P Type Engine	Body	Supplemental Inflatable Restraint																																																									
D	2012	P Type Engine	Body	TV Antenna Module																																																									
D	2012	P Type Engine	Body	Vehicle Comm. Interface Module																																																									
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto	V			V					V																																																
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual	V			V					V																																																
D	2012	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module		V																																																								
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module											V	V																																													
D	2012	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module	V			V					V																																																	
D	2012	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																										
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module		V																																																								
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module											V	V																																														
D	2012	Other	Chassis	Electronic Brake Control Module						V							V	V																																													
D	2012	Other	Chassis	Electronic Suspension Control																																																											
D	2012	Other	Chassis	Parking Brake Control Module																																																										
D	2012	Other	Body	Body Control Module															V	V		V	V		V		V	V																																		
D	2012	Other	Body	Body Control Module (aux.)																																																										
D	2012	Other	Body	Driver Door Switch																																																										
D	2012	Other	Body	Headlamp Control Module																								V	V	V																																	
D	2012	Other	Body	HVAC Control Module																											V	V	V																														
D	2012	Other	Body	Instrument Panel Cluster																																																										
D	2012	Other	Body	Left Side Object Detection Module																																								V					V													
D	2012	Other	Body	Liftgate Module																																																										
D	2012	Other	Body	Memory Seat Module																															V	V	V	V	V	V	V	V	V																				
D	2012	Other	Body	Park Assist Module																																								V	V	V																
D	2012	Other	Body	Passenger Door Switch																																																										
D	2012	Other	Body	Passenger Presence System																																											V															
D	2012	Other	Body	Pedestrian Impact Detection Module																																													V	V	V	V										
D	2012	Other	Body	Radio																																																V	V	V							
D	2012	Other	Body	Right Side Object Detection Module																																								V					V													
D	2012	Other	Body	Supplemental Inflatable Restraint																																																										
D	2012	Other	Body	TV Antenna Module																																																										
D	2012	Other	Body	Vehicle Comm. Interface Module																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto	V			V																																																						
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual	V			V																																																						
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module		V																																																								
D	2013	P Type Engine	Chassis	Electronic Brake Control Module						V							V	V																																													
D	2013	P Type Engine	Chassis	Electronic Suspension Control																																																											
D	2013	P Type Engine	Chassis	Parking Brake Control Module																																																										
D	2013	P Type Engine	Body	Body Control Module															V	V		V	V		V		V	V																																		
D	2013	P Type Engine	Body	Body Control Module (aux.)																																																										
D	2013	P Type Engine	Body	Driver Door Switch																																																										
D	2013	P Type Engine	Body	Headlamp Control Module																								V	V	V																																	

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2013	P Type Engine	Body	HVAC Control Module																												V	V	V																											
D	2013	P Type Engine	Body	Instrument Panel Cluster																																																									
D	2013	P Type Engine	Body	Left Side Object Detection Module																																								V					V												
D	2013	P Type Engine	Body	Liftgate Module																																																								
D	2013	P Type Engine	Body	Memory Seat Module																															V	V	V	V	V	V	V	V	V																		
D	2013	P Type Engine	Body	Park Assist Module																																							V	V	V															
D	2013	P Type Engine	Body	Passenger Door Switch																																																								
D	2013	P Type Engine	Body	Passenger Presence System																																										V														
D	2013	P Type Engine	Body	Pedestrian Impact Detection Module																																											V	V	V	V									
D	2013	P Type Engine	Body	Radio																																															V	V	V						
D	2013	P Type Engine	Body	Right Side Object Detection Module																																							V					V												
D	2013	P Type Engine	Body	Supplemental Inflatable Restraint																																																								
D	2013	P Type Engine	Body	TV Antenna Module																																																								
D	2013	P Type Engine	Body	Vehicle Comm. Interface Module																																																								
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto	V			V					V																																																
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual	V			V					V																																																
D	2013	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																									
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module		V																																																							
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module											V	V																																													
D	2013	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module	V			V					V																																																
D	2013	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																									
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module		V																																																							
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module											V	V																																													
D	2013	Other	Chassis	Electronic Brake Control Module						V							V	V																																												
D	2013	Other	Chassis	Electronic Suspension Control																																																									
D	2013	Other	Chassis	Parking Brake Control Module																																																									
D	2013	Other	Body	Body Control Module															V	V		V	V		V		V	V																																	
D	2013	Other	Body	Body Control Module (aux.)																																																									
D	2013	Other	Body	Driver Door Switch																																																									
D	2013	Other	Body	Headlamp Control Module																									V	V	V																															
D	2013	Other	Body	HVAC Control Module																												V	V	V																												
D	2013	Other	Body	Instrument Panel Cluster																																																									
D	2013	Other	Body	Left Side Object Detection Module																																								V					V												
D	2013	Other	Body	Liftgate Module																																																									
D	2013	Other	Body	Memory Seat Module																															V	V	V	V	V	V	V	V	V																		
D	2013	Other	Body	Park Assist Module																																							V	V	V															
D	2013	Other	Body	Passenger Door Switch																																																									
D	2013	Other	Body	Passenger Presence System																																										V														
D	2013	Other	Body	Pedestrian Impact Detection Module																																											V	V	V	V									
D	2013	Other	Body	Radio																																															V	V	V						
D	2013	Other	Body	Right Side Object Detection Module																																								V					V												
D	2013	Other	Body	Supplemental Inflatable Restraint																																																									
D	2013	Other	Body	TV Antenna Module																																																									
D	2013	Other	Body	Vehicle Comm. Interface Module																																																									
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
D	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																									
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																									
D	2014	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																									
D	2014	CTS	Powertrain	Chassis Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2014	CTS	Powertrain	Transfer Case Control Module																																																											
D	2014	CTS	Chassis	Electronic Brake Control Module																																																												
D	2014	CTS	Chassis	Parking Brake Control Module																																																												
D	2014	CTS	Chassis	Suspension Control Module																																																												
D	2014	CTS	Body	Body Control Module Coupe																																																												
D	2014	CTS	Body	Body Control Module Station Wagon																																																												
D	2014	CTS	Body	Auxiliary Body Control Module																																																												
D	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2014	CTS	Body	Passenger Presence Module																																																												
D	2014	CTS	Body	Pedestrian Impact Detection Module																																																												
D	2014	CTS	Body	Instrument Cluster																																																												
D	2014	CTS	Body	Headlamp Control Module																																																												
D	2014	CTS	Body	Radio																																																												
D	2014	CTS	Body	Amplifier																																																												
D	2014	CTS	Body	Television Antenna Module																																																												
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																												
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																												
D	2014	CTS	Body	HVAC Control Module																																																												
D	2014	CTS	Body	Driver Door Switch Panel Control Module																																																												
D	2014	CTS	Body	Passenger Door Switch Panel Control Module																																																												
D	2014	CTS	Body	Liftgate Control Module																																																												
D	2014	CTS	Body	Seat Memory Control Module																																																												
D	2014	CTS	Body	Right Side Object Detection Control Module																																																												
D	2014	CTS	Body	Left Side Object Detection Control Module																																																												
D	2014	CTS	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																												
D	2014	CTS	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
D	2014	CTS	Body	Parking Assist Control Module																																																												
D	2014	CTS	Body	Theft Deterrent Module																																																												
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
D	2015	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																												
D	2015	CTS	Powertrain	Chassis Control Module																																																												
D	2015	CTS	Powertrain	Transfer Case Control Module																																																												
D	2015	CTS	Chassis	Electronic Brake Control Module																																																												
D	2015	CTS	Chassis	Parking Brake Control Module																																																												
D	2015	CTS	Chassis	Suspension Control Module																																																												
D	2015	CTS	Body	Body Control Module Coupe																																																												
D	2015	CTS	Body	Body Control Module Station Wagon																																																												
D	2015	CTS	Body	Auxiliary Body Control Module																																																												
D	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2015	CTS	Body	Passenger Presence Module																																																												
D	2015	CTS	Body	Pedestrian Impact Detection Module																																																												
D	2015	CTS	Body	Instrument Cluster																																																												
D	2015	CTS	Body	Headlamp Control Module																																																												
D	2015	CTS	Body	Radio																																																											
D	2015	CTS	Body	Amplifier																																																											
D	2015	CTS	Body	Television Antenna Module																																																												
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 9																																																												
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																												
D	2015	CTS	Body	HVAC Control Module																																																												
D	2015	CTS	Body	Driver Door Switch Panel Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2015	CTS	Body	Passenger Door Switch Panel Control Module																																																										
D	2015	CTS	Body	Liftgate Control Module																																																										
D	2015	CTS	Body	Seat Memory Control Module																																																										
D	2015	CTS	Body	Right Side Object Detection Control Module																																																										
D	2015	CTS	Body	Left Side Object Detection Control Module																																																										
D	2015	CTS	Body	Remote Control Door Lock Receiver																																																										
D	2015	CTS	Body	Parking Assist Control Module																																																										
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2004	(KD)Deville	Body	Amplifier (Delco)																																																										
K	2004	(KD)Deville	Body	CD Changer																																																										
K	2004	(KD)Deville	Body	Dash Integration Module																																																										
K	2004	(KD)Deville	Body	Digital Radio Receiver																																																										
K	2004	(KD)Deville	Body	Driver Door Switch																																																										
K	2004	(KD)Deville	Body	Driver Door Module																																																										
K	2004	(KD)Deville	Body	Passenger Door Module																																																										
K	2004	(KD)Deville	Body	Left Rear Door Module																																																										
K	2004	(KD)Deville	Body	Right Rear Door Module																																																										
K	2004	(KD)Deville	Body	Instrument Panel Cluster																																																										
K	2004	(KD)Deville	Body	Instrument Panel Module																												V																														
K	2004	(KD)Deville	Body	Memory Seat Module																																																										
K	2004	(KD)Deville	Body	Navigation Radio																																																										
K	2004	(KD)Deville	Body	Radio																																																										
K	2004	(KD)Deville	Body	Rear Climate Control Panel																																																										
K	2004	(KD)Deville	Body	Rear Integration Module																																																										
K	2004	(KD)Deville	Body	Remote Function Actuation																																																										
K	2004	(KD)Deville	Body	Supplemental Inflatable Restraint																																																										
K	2004	(KD)Deville	Body	Tilt Telescope Module																																																										
K	2004	(KD)Deville	Body	Vehicle Theft Deterrent																																																										
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2004	(KE)DHS	Body	Amplifier (Bose)																																																										
K	2004	(KE)DHS	Body	CD Changer																																																										
K	2004	(KE)DHS	Body	Dash Integration Module																																																										
K	2004	(KE)DHS	Body	Digital Radio Receiver																																																										
K	2004	(KE)DHS	Body	Driver Door Switch																																																										
K	2004	(KE)DHS	Body	Driver Door Module																																																										
K	2004	(KE)DHS	Body	Passenger Door Module																																																										
K	2004	(KE)DHS	Body	Left Rear Door Module																																																										
K	2004	(KE)DHS	Body	Right Rear Door Module																																																										
K	2004	(KE)DHS	Body	Instrument Panel Cluster																																																										
K	2004	(KE)DHS	Body	Instrument Panel Module																												V																														
K	2004	(KE)DHS	Body	Memory Seat Module																																																										
K	2004	(KE)DHS	Body	Navigation Radio																																																										
K	2004	(KE)DHS	Body	Radio																																																										
K	2004	(KE)DHS	Body	Rear Climate Control Panel																																																										
K	2004	(KE)DHS	Body	Rear Integration Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2004	(KE)DHS	Body	Remote Function Actuation																																																											
K	2004	(KE)DHS	Body	Supplemental Inflatable Restraint																																																											
K	2004	(KE)DHS	Body	Tilt Telescope Module																																																											
K	2004	(KE)DHS	Body	Vehicle Theft Deterrent																																																											
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																											
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																											
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																											
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																											
K	2004	(KF)DTS	Body	Amplifier (Bose)																																																												
K	2004	(KF)DTS	Body	CD Changer																																																												
K	2004	(KF)DTS	Body	Dash Integration Module																																																												
K	2004	(KF)DTS	Body	Digital Radio Receiver																																																												
K	2004	(KF)DTS	Body	Driver Door Switch																																																												
K	2004	(KF)DTS	Body	Driver Door Module																																																												
K	2004	(KF)DTS	Body	Passenger Door Module																																																												
K	2004	(KF)DTS	Body	Left Rear Door Module																																																												
K	2004	(KF)DTS	Body	Right Rear Door Module																																																												
K	2004	(KF)DTS	Body	Instrument Panel Cluster																																																												
K	2004	(KF)DTS	Body	Instrument Panel Module																												V																																
K	2004	(KF)DTS	Body	Memory Seat Module																																																												
K	2004	(KF)DTS	Body	Navigation Radio																																																												
K	2004	(KF)DTS	Body	Radio																																																												
K	2004	(KF)DTS	Body	Rear Climate Control Panel																																																												
K	2004	(KF)DTS	Body	Rear Integration Module																																																												
K	2004	(KF)DTS	Body	Remote Function Actuation																																																												
K	2004	(KF)DTS	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KF)DTS	Body	Tilt Telescope Module																																																												
K	2004	(KF)DTS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																												
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																												
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																												
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																												
K	2004	(KS)Seville SLS	Body	Amplifier (Bose)																																																												
K	2004	(KS)Seville SLS	Body	Amplifier (Delco)																																																												
K	2004	(KS)Seville SLS	Body	CD Changer																																																												
K	2004	(KS)Seville SLS	Body	Dash Integration Module																																																												
K	2004	(KS)Seville SLS	Body	Digital Radio Receiver																																																												
K	2004	(KS)Seville SLS	Body	Driver Door Module																																																												
K	2004	(KS)Seville SLS	Body	Instrument Panel Cluster																																																												
K	2004	(KS)Seville SLS	Body	Instrument Panel Module																												V																																
K	2004	(KS)Seville SLS	Body	Memory Seat Module																																																												
K	2004	(KS)Seville SLS	Body	Navigation Radio																																																												
K	2004	(KS)Seville SLS	Body	Radio																																																												
K	2004	(KS)Seville SLS	Body	Rear Integration Module																																																												
K	2004	(KS)Seville SLS	Body	Remote Function Actuation																																																												
K	2004	(KS)Seville SLS	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KS)Seville SLS	Body	Tilt Telescope Module																																																												
K	2004	(KS)Seville SLS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																												
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																												
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2004	(KY)Seville STS	Body	Amplifier (Bose)																																																											
K	2004	(KY)Seville STS	Body	Amplifier (Delco)																																																											
K	2004	(KY)Seville STS	Body	CD Changer																																																											
K	2004	(KY)Seville STS	Body	Dash Integration Module																																																											
K	2004	(KY)Seville STS	Body	Digital Radio Receiver																																																											
K	2004	(KY)Seville STS	Body	Driver Door Module																																																											
K	2004	(KY)Seville STS	Body	Instrument Panel Cluster																																																											
K	2004	(KY)Seville STS	Body	Instrument Panel Module																												V																																
K	2004	(KY)Seville STS	Body	Memory Seat Module																																																											
K	2004	(KY)Seville STS	Body	Navigation Radio																																																											
K	2004	(KY)Seville STS	Body	Radio																																																											
K	2004	(KY)Seville STS	Body	Rear Integration Module																																																											
K	2004	(KY)Seville STS	Body	Remote Function Actuation																																																											
K	2004	(KY)Seville STS	Body	Supplemental Inflatable Restraint																																																											
K	2004	(KY)Seville STS	Body	Tilt Telescope Module																																																											
K	2004	(KY)Seville STS	Body	Vehicle Theft Deterrent																																																											
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																											
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																											
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																											
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																											
K	2005	(KD)Deville	Body	Amplifier (Delco)																																																											
K	2005	(KD)Deville	Body	CD Changer																																																											
K	2005	(KD)Deville	Body	Dash Integration Module																																																											
K	2005	(KD)Deville	Body	Digital Radio Receiver																																																											
K	2005	(KD)Deville	Body	Driver Door Switch																																																											
K	2005	(KD)Deville	Body	Driver Door Module																																																											
K	2005	(KD)Deville	Body	Passenger Door Module																																																											
K	2005	(KD)Deville	Body	Left Rear Door Module																																																											
K	2005	(KD)Deville	Body	Right Rear Door Module																																																											
K	2005	(KD)Deville	Body	Instrument Panel Cluster																																																											
K	2005	(KD)Deville	Body	Instrument Panel Module																												V																																
K	2005	(KD)Deville	Body	Memory Seat Module																																																											
K	2005	(KD)Deville	Body	Navigation Radio																																																											
K	2005	(KD)Deville	Body	Radio																																																											
K	2005	(KD)Deville	Body	Rear Climate Control Panel																																																											
K	2005	(KD)Deville	Body	Rear Integration Module																																																											
K	2005	(KD)Deville	Body	Remote Function Actuation																																																											
K	2005	(KD)Deville	Body	Supplemental Inflatable Restraint																																																											
K	2005	(KD)Deville	Body	Tilt Telescope Module																																																											
K	2005	(KD)Deville	Body	Vehicle Theft Deterrent																																																											
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																											
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																											
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																											
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																											
K	2005	(KE)DHS	Body	Amplifier (Bose)																																																											
K	2005	(KE)DHS	Body	CD Changer																																																											
K	2005	(KE)DHS	Body	Dash Integration Module																																																											
K	2005	(KE)DHS	Body	Digital Radio Receiver																																																											
K	2005	(KE)DHS	Body	Driver Door Switch																																																											
K	2005	(KE)DHS	Body	Driver Door Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2005	(KE)DHS	Body	Passenger Door Module																																																										
K	2005	(KE)DHS	Body	Left Rear Door Module																																																										
K	2005	(KE)DHS	Body	Right Rear Door Module																																																										
K	2005	(KE)DHS	Body	Instrument Panel Cluster																																																										
K	2005	(KE)DHS	Body	Instrument Panel Module																												V																														
K	2005	(KE)DHS	Body	Memory Seat Module																																																										
K	2005	(KE)DHS	Body	Navigation Radio																																																										
K	2005	(KE)DHS	Body	Radio																																																										
K	2005	(KE)DHS	Body	Rear Climate Control Panel																																																										
K	2005	(KE)DHS	Body	Rear Integration Module																																																										
K	2005	(KE)DHS	Body	Remote Function Actuation																																																										
K	2005	(KE)DHS	Body	Supplemental Inflatable Restraint																																																										
K	2005	(KE)DHS	Body	Tilt Telescope Module																																																										
K	2005	(KE)DHS	Body	Vehicle Theft Deterrent																																																										
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2005	(KF)DTS	Body	Amplifier (Bose)																																																										
K	2005	(KF)DTS	Body	CD Changer																																																										
K	2005	(KF)DTS	Body	Dash Integration Module																																																										
K	2005	(KF)DTS	Body	Digital Radio Receiver																																																										
K	2005	(KF)DTS	Body	Driver Door Switch																																																										
K	2005	(KF)DTS	Body	Driver Door Module																																																										
K	2005	(KF)DTS	Body	Passenger Door Module																																																										
K	2005	(KF)DTS	Body	Left Rear Door Module																																																										
K	2005	(KF)DTS	Body	Right Rear Door Module																																																										
K	2005	(KF)DTS	Body	Instrument Panel Cluster																																																										
K	2005	(KF)DTS	Body	Instrument Panel Module																												V																														
K	2005	(KF)DTS	Body	Memory Seat Module																																																										
K	2005	(KF)DTS	Body	Navigation Radio																																																										
K	2005	(KF)DTS	Body	Radio																																																										
K	2005	(KF)DTS	Body	Rear Climate Control Panel																																																										
K	2005	(KF)DTS	Body	Rear Integration Module																																																										
K	2005	(KF)DTS	Body	Remote Function Actuation																																																										
K	2005	(KF)DTS	Body	Supplemental Inflatable Restraint																																																										
K	2005	(KF)DTS	Body	Tilt Telescope Module																																																										
K	2005	(KF)DTS	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Powertrain	Engine Control Module	V																																																									
K	2006	ALL	Powertrain	Automatic Transaxle																																																										
K	2006	ALL	Chassis	Antilock Brake System																																																										
K	2006	ALL	Body	Amplifier (Bose)																																																										
K	2006	ALL	Body	Aux. HVAC Control Module																																																										
K	2006	ALL	Body	Body Control Module														V	V	V	V	V	V	V		V	V																																			
K	2006	ALL	Body	Digital Radio Receiver																																																										
K	2006	ALL	Body	Distance Sensing Cruise Control																																																										
K	2006	ALL	Body	Driver Door Switch																																																										
K	2006	ALL	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																				
K	2006	ALL	Body	HVAC Control Module																												V	V																													
K	2006	ALL	Body	Instrument Panel Cluster																																																										
K	2006	ALL	Body	Park Assist Module																																							V	V	V																	

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2006	ALL	Body	Passenger Door Switch																																																								
K	2006	ALL	Body	Passenger Presence System																																									V															
K	2006	ALL	Body	Radio																																																							
K	2006	ALL	Body	Rear Heated Seat Module																																	V				V																			
K	2006	ALL	Body	Remote Control Door Lock Receiver																																																							
K	2006	ALL	Body	Supplemental Inflatable Restraint																																									V									V					
K	2006	ALL	Body	Theft Deterrent Module																																																							
K	2006	ALL	Body	TV Antenna Module																																																							
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																							
K	2007	ALL	Powertrain	Engine Control Module	V																																																							
K	2007	ALL	Powertrain	Transmission Control Module																																																							
K	2007	ALL	Chassis	Electronic Brake Control Module																																																							
K	2007	ALL	Body	Amplifier (Bose)																																																							
K	2007	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																							
K	2007	ALL	Body	Body Control Module															V	V	V	V	V	V	V		V	V																																
K	2007	ALL	Body	Digital Radio Receiver																																																							
K	2007	ALL	Body	Distance Sensing Cruise Control																																																							
K	2007	ALL	Body	Driver Door Switch																																																							
K	2007	ALL	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																		
K	2007	ALL	Body	CJ2 Dual Zone HVAC Auto																											V	V																												
K	2007	ALL	Body	CJ4 Tri Zone HVAC Auto																											V	V																												
K	2007	ALL	Body	Inside Rear View Mirror Module																																																							
K	2007	ALL	Body	Instrument Panel Cluster																																																							
K	2007	ALL	Body	Park Assist Module																																							V	V	V															
K	2007	ALL	Body	Passenger Door Switch																																																							
K	2007	ALL	Body	Passenger Presence System																																									V															
K	2007	ALL	Body	Radio																																																							
K	2007	ALL	Body	Rear Heated Seat Module																																	V				V																			
K	2007	ALL	Body	Supplemental Inflatable Restraint																																									V									V					
K	2007	ALL	Body	Theft Deterrent Module																																																							
K	2007	ALL	Body	TV Antenna Module																																																							
K	2007	ALL	Body	Vehicle Comm. Interface Module																																																							
K	2008	ALL	Powertrain	Engine Control Module	V																																																							
K	2008	ALL	Powertrain	Transmission Control Module																																																							
K	2008	ALL	Chassis	Electronic Brake Control Module						V						V	V																																											
K	2008	ALL	Body	Amplifier (Bose)																																																							
K	2008	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																							
K	2008	ALL	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V																																
K	2008	ALL	Body	Digital Radio Receiver																																																							
K	2008	ALL	Body	Distance Sensing Cruise Control																																																							
K	2008	ALL	Body	Driver Door Switch																																																							
K	2008	ALL	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																		
K	2008	ALL	Body	CJ2 Dual Zone HVAC Auto																											V	V																												
K	2008	ALL	Body	CJ4 Tri Zone HVAC Auto																											V	V																												
K	2008	ALL	Body	Inside Rear View Mirror Module																																																							
K	2008	ALL	Body	Instrument Panel Cluster																																																							
K	2008	ALL	Body	Left Side Object Detection Module																																								V					V											
K	2008	ALL	Body	Park Assist Module																																							V	V	V															
K	2008	ALL	Body	Passenger Door Switch																																																							
K	2008	ALL	Body	Passenger Presence System																																									V															
K	2008	ALL	Body	Radio																																																							

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2008	ALL	Body	Rear Heated Seat Module																																		V				V																			
K	2008	ALL	Body	Right Side Object Detection Module																																								V						V										
K	2008	ALL	Body	Supplemental Inflatable Restraint																																									V									V					
K	2008	ALL	Body	Theft Deterrent Module																																																							
K	2008	ALL	Body	TV Antenna Module																																																							
K	2008	ALL	Body	Vehicle Comm. Interface Module																																																							
K	2008	ALL	Body	Veh Direction Alert Alarm Warn Mod																																								V																
K	2009	ALL	Powertrain	Engine Control Module	V																																																						
K	2009	ALL	Powertrain	Transmission Control Module																																																							
K	2009	ALL	Chassis	Electronic Brake Control Module						V							V	V																																										
K	2009	ALL	Body	Amplifier (Bose)																																																							
K	2009	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																							
K	2009	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V																																
K	2009	ALL	Body	Digital Radio Receiver																																																							
K	2009	ALL	Body	Distance Sensing Cruise Control																																																							
K	2009	ALL	Body	Driver Door Switch																																																							
K	2009	ALL	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																		
K	2009	ALL	Body	CJ2 Dual Zone HVAC Auto																											V	V																												
K	2009	ALL	Body	CJ4 Tri Zone HVAC Auto																											V	V																												
K	2009	ALL	Body	Inside Rear View Mirror Module																																																							
K	2009	ALL	Body	Instrument Panel Cluster																																																							
K	2009	ALL	Body	Left Side Object Detection Module																																								V						V										
K	2009	ALL	Body	Park Assist Module																																							V	V	V														
K	2009	ALL	Body	Passenger Door Switch																																																							
K	2009	ALL	Body	Passenger Presence System																																									V															
K	2009	ALL	Body	Radio																																																							
K	2009	ALL	Body	Rear Heated Seat Module																																		V				V																		
K	2009	ALL	Body	Right Side Object Detection Module																																								V						V										
K	2009	ALL	Body	Supplemental Inflatable Restraint																																									V									V					
K	2009	ALL	Body	Theft Deterrent Module																																																							
K	2009	ALL	Body	TV Antenna Module																																																							
K	2009	ALL	Body	Vehicle Comm. Interface Module																																																							
K	2009	ALL	Body	Vehicle Comm. Interface Module																																																							
K	2009	ALL	Body	Veh Direction Alert Alarm Warn Mod																																								V																
K	2010	ALL	Powertrain	Engine Control Module	V																																																						
K	2010	ALL	Powertrain	Transmission Control Module																																																							
K	2010	ALL	Chassis	Electronic Brake Control Module						V							V	V																																										
K	2010	ALL	Body	Amplifier (Bose)																																																							
K	2010	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																							
K	2010	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V																																
K	2010	ALL	Body	Digital Radio Receiver																																																							
K	2010	ALL	Body	Distance Sensing Cruise Control																																																							
K	2010	ALL	Body	Driver Door Switch																																																							
K	2010	ALL	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																		
K	2010	ALL	Body	CJ2 Dual Zone HVAC Auto																											V	V																												
K	2010	ALL	Body	CJ4 Tri Zone HVAC Auto																											V	V																												
K	2010	ALL	Body	Inside Rear View Mirror Module																																																							
K	2010	ALL	Body	Instrument Panel Cluster																																																							
K	2010	ALL	Body	Left Side Object Detection Module																																								V						V										
K	2010	ALL	Body	Park Assist Module																																							V	V	V														
K	2010	ALL	Body	Passenger Door Switch																																																							

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2010	ALL	Body	Passenger Presence System																																										V															
K	2010	ALL	Body	Radio																																																								
K	2010	ALL	Body	Rear Heated Seat Module																																	V				V																				
K	2010	ALL	Body	Right Side Object Detection Module																																								V				V												
K	2010	ALL	Body	Supplemental Inflatable Restraint																																									V									V					
K	2010	ALL	Body	Theft Deterrent Module																																																							
K	2010	ALL	Body	TV Antenna Module																																																							
K	2010	ALL	Body	Vehicle Comm. Interface Module																																																							
K	2010	ALL	Body	Veh Direction Alert Alarm Warn Mod																																							V																	
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Engine Control Module	V																																																						
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Transmission Control Module																																																							
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Engine Control Module	V																																																						
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Transmission Control Module																																																							
K	2011	ALL	Chassis	Electronic Brake Control Module						V						V	V																																											
K	2011	ALL	Body	Amplifier (Bose)																																																							
K	2011	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																							
K	2011	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V																																
K	2011	ALL	Body	Digital Radio Receiver																																																							
K	2011	ALL	Body	Distance Sensing Cruise Control																																																							
K	2011	ALL	Body	Driver Door Switch																																																							
K	2011	ALL	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																		
K	2011	ALL	Body	CJ2 Dual Zone HVAC Auto																												V	V																											
K	2011	ALL	Body	CJ4 Tri Zone HVAC Auto																												V	V																											
K	2011	ALL	Body	Inside Rear View Mirror Module																																																							
K	2011	ALL	Body	Instrument Panel Cluster																																																							
K	2011	ALL	Body	Left Side Object Detection Module																																								V				V												
K	2011	ALL	Body	Park Assist Module																																							V	V	V															
K	2011	ALL	Body	Passenger Door Switch																																																							
K	2011	ALL	Body	Passenger Presence System																																									V															
K	2011	ALL	Body	Radio																																																							
K	2011	ALL	Body	Rear Heated Seat Module																																	V				V																			
K	2011	ALL	Body	Right Side Object Detection Module																																								V				V												
K	2011	ALL	Body	Supplemental Inflatable Restraint																																									V									V					
K	2011	ALL	Body	Theft Deterrent Module																																																							
K	2011	ALL	Body	TV Antenna Module																																																							
K	2011	ALL	Body	Vehicle Comm. Interface Module																																																							
K	2011	ALL	Body	Veh Direction Alert Alarm Warn Mod																																								V															
K	2016	CT6	Powertrain	(X) 2.0L LTG Engine Control Module																																																							
K	2016	CT6	Powertrain	(X) 2.0L LTG Transmission Control Module																																																							
K	2016	CT6	Powertrain	(6) 3.0L LGW Engine Control Module																																																							
K	2016	CT6	Powertrain	(6) 3.0L LGW Transmission Control Module																																																							
K	2016	CT6	Powertrain	(S) 3.6L LGX Engine Control Module																																																							
K	2016	CT6	Powertrain	(S) 3.6L LGX Transmission Control Module																																																							
K	2016	CT6	Powertrain	Transfer Case Control Module																																																							
K	2016	CT6	Chassis	Electronic Brake Control Module																																																							
K	2016	CT6	Chassis	Brake Booster Control Module																																																							
K	2016	CT6	Chassis	Power Steering Control Module																																																							
K	2016	CT6	Chassis	Rear Wheel Steering Control Module																																																							
K	2016	CT6	Chassis	Suspension Control Module																																																							
K	2016	CT6	Body	Body Control Module																																																							
K	2016	CT6	Body	Serial Data Gateway Module																																																							

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2016	CT6	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	CT6	Body	Passenger Presence Module																																																											
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Left																																																										
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Right																																																										
K	2016	CT6	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
K	2016	CT6	Body	Instrument Cluster Full Screen Display (UDV)																																																										
K	2016	CT6	Body	Radio Controls																																																										
K	2016	CT6	Body	HVAC Controls																																																										
K	2016	CT6	Body	Active Safety Control Module																																																										
K	2016	CT6	Body	Video Processing Control Module																																																										
K	2016	CT6	Body	Headlamp Control Module																																																										
K	2016	CT6	Body	Trailer Interface Control Module																																																										
K	2016	CT6	Body	Radio																																																										
K	2016	CT6	Body	Amplifier																																																										
K	2016	CT6	Body	Infotainment Control Touchpad																																																										
K	2016	CT6	Body	Human Machine Interface Control Module																																																										
K	2016	CT6	Body	Navigation Control Module																																																										
K	2016	CT6	Body	Telematics Communication Interface Control Module																																																										
K	2016	CT6	Body	HVAC Control Module																																																										
K	2016	CT6	Body	Liftgate Control Module																																																										
K	2016	CT6	Body	Seat Memory Control Module - Passenger																																																										
K	2016	CT6	Body	Seat Memory Control Module - Left Rear																																																										
K	2016	CT6	Body	Seat Memory Control Module - Driver																																																										
K	2016	CT6	Body	Seat Memory Control Module - Right Rear																																																										
K	2016	CT6	Body	Keyless Entry Control Module																																																										
K	2016	CT6	Body	Left Side Object Detection Control Module																																																										
K	2016	CT6	Body	Parking Assist Control Module																																																										
K	2016	CT6	Body	Frontview Camera Module																																																										
K	2016	CT6	Body	Long Range Radar Sensor Module																																																										
K	2016	CT6	Body	Left Front Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Right Front Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Rear Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Night Vision Camera Control Module																																																										
R	2014	ELR	Powertrain	Engine Control Module																																																										
R	2014	ELR	Powertrain	Trasmission Control Module																																																										
R	2014	ELR	Powertrain	Chassis Control Module																																																										
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module																																																										
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2014	ELR	Powertrain	Drive Motor Control Module 1																																																										
R	2014	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2014	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2014	ELR	Chassis	Electronic Brake Control Module																																																										
R	2014	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2014	ELR	Chassis	Parking Brake Control Module																																																										
R	2014	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2014	ELR	Chassis	Power Steering Control Module																																																										
R	2014	ELR	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2014	ELR	Chassis	Suspension Control Module																																																										
R	2014	ELR	Body	Body Control Module																																																										
R	2014	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2014	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2014	ELR	Body	Passenger Presence Module																																																										
R	2014	ELR	Body	Instrument Cluster																																																										
R	2014	ELR	Body	Radio/HVAC Control																																																										
R	2014	ELR	Body	Radio																																																										
R	2014	ELR	Body	Amplifier																																																										
R	2014	ELR	Body	Human Machine Interface Control Module																																																											
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2014	ELR	Body	HVAC Control Module																																																											
R	2014	ELR	Body	Electric A/C Compressor Control Module																																																											
R	2014	ELR	Body	Coolant Heater Control Module																																																											
R	2014	ELR	Body	Seat Memory Control Module - Driver																																																											
R	2014	ELR	Body	Keyless Entry Control Module																																																											
R	2014	ELR	Body	Right Side Object Detection Control Module																																																											
R	2014	ELR	Body	Left Side Object Detection Control Module																																																											
R	2014	ELR	Body	Parking Assist Control Module																																																											
R	2014	ELR	Body	Frontview Camera Module																																																											
R	2014	ELR	Body	Steering Column Lock Control Module																																																											
R	2014	ELR	Body	Battery Charger Control Module																																																											
R	2014	ELR	Body	Battery Energy Control Module																																																											
R	2015	ELR	Powertrain	Engine Control Module																																																											
R	2015	ELR	Powertrain	Trasmission Control Module																																																											
R	2015	ELR	Powertrain	Chassis Control Module																																																											
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module																																																											
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2015	ELR	Powertrain	Drive Motor Control Module 1																																																											
R	2015	ELR	Powertrain	Drive Motor Control Module 2																																																											
R	2015	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2015	ELR	Chassis	Electronic Brake Control Module																																																											
R	2015	ELR	Chassis	Distance Sensing Cruise Control Module																																																											
R	2015	ELR	Chassis	Parking Brake Control Module																																																											
R	2015	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																											
R	2015	ELR	Chassis	Power Steering Control Module																																																											
R	2015	ELR	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2015	ELR	Chassis	Suspension Control Module																																																											
R	2015	ELR	Body	Body Control Module																																																											
R	2015	ELR	Body	Pedestrian Impact Detection Module																																																											
R	2015	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2015	ELR	Body	Passenger Presence Module																																																											
R	2015	ELR	Body	Instrument Cluster																																																											
R	2015	ELR	Body	Radio/HVAC Control																																																											
R	2015	ELR	Body	Headlamp Control Module																																																											
R	2015	ELR	Body	Radio																																																											
R	2015	ELR	Body	Amplifier																																																											
R	2015	ELR	Body	Human Machine Interface Control Module																																																											
R	2015	ELR	Body	Telematics Communication Interface Control Module																																																											
R	2015	ELR	Body	HVAC Control Module																																																											
R	2015	ELR	Body	Electric A/C Compressor Control Module																																																											
R	2015	ELR	Body	Coolant Heater Control Module																																																											
R	2015	ELR	Body	Seat Memory Control Module - Driver																																																											
R	2015	ELR	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2015	ELR	Body	Right Side Object Detection Control Module																																																										
R	2015	ELR	Body	Left Side Object Detection Control Module																																																											
R	2015	ELR	Body	Parking Assist Control Module																																																											
R	2015	ELR	Body	Frontview Camera Module																																																											
R	2015	ELR	Body	Steering Column Lock Control Module																																																											
R	2015	ELR	Body	Battery Charger Control Module																																																											
R	2015	ELR	Body	Battery Energy Control Module																																																											
R	2016	ELR	Powertrain	Engine Control Module																																																											
R	2016	ELR	Powertrain	Trasmission Control Module																																																											
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module																																																											
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2016	ELR	Powertrain	Drive Motor Control Module 1																																																											
R	2016	ELR	Powertrain	Drive Motor Control Module 2																																																											
R	2016	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2016	ELR	Chassis	Electronic Brake Control Module																																																											
R	2016	ELR	Chassis	Distance Sensing Cruise Control Module																																																											
R	2016	ELR	Chassis	Parking Brake Control Module																																																											
R	2016	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																											
R	2016	ELR	Chassis	Power Steering Control Module																																																											
R	2016	ELR	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2016	ELR	Chassis	Suspension Control Module																																																											
R	2016	ELR	Body	Body Control Module																																																											
R	2016	ELR	Body	Pedestrian Impact Detection Module																																																											
R	2016	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2016	ELR	Body	Passenger Presence Module																																																											
R	2016	ELR	Body	Instrument Cluster																																																											
R	2016	ELR	Body	Radio/HVAC Control																																																											
R	2016	ELR	Body	Headlamp Control Module																																																											
R	2016	ELR	Body	Radio																																																											
R	2016	ELR	Body	Amplifier																																																											
R	2016	ELR	Body	Human Machine Interface Control Module																																																											
R	2016	ELR	Body	Telematics Communication Interface Control Module																																																											
R	2016	ELR	Body	HVAC Control Module																																																											
R	2016	ELR	Body	Electric A/C Compressor Control Module																																																											
R	2016	ELR	Body	Coolant Heater Control Module																																																											
R	2016	ELR	Body	Seat Memory Control Module - Driver																																																											
R	2016	ELR	Body	Keyless Entry Control Module																																																											
R	2016	ELR	Body	Left Side Object Detection Control Module																																																											
R	2016	ELR	Body	Parking Assist Control Module																																																											
R	2016	ELR	Body	Frontview Camera Module																																																											
R	2016	ELR	Body	Steering Column Lock Control Module																																																											
R	2016	ELR	Body	Battery Charger Control Module																																																											
R	2016	ELR	Body	Battery Energy Control Module																																																											
Y	2004	ALL	Powertrain	Engine Control Module																																																											
Y	2004	ALL	Powertrain	Automatic Transmission																																																											
Y	2004	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2004	ALL	Chassis	Electronic Suspension Control																																																											
Y	2004	ALL	Chassis	Steering Wheel and Column																																																											
Y	2004	ALL	Body	Amplifier (Bose)																																																											
Y	2004	ALL	Body	Body Control Module															V			V	V				V	V																																		
Y	2004	ALL	Body	CD Changer																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Y	2004	ALL	Body	Digital Radio Receiver																																																											
Y	2004	ALL	Body	Distance Sensing Cruise Control																																																											
Y	2004	ALL	Body	Driver Door Module																																																											
Y	2004	ALL	Body	Driver Door Switch																																																											
Y	2004	ALL	Body	Driver Position Module																																																											
Y	2004	ALL	Body	Folding Top Module																																																											
Y	2004	ALL	Body	Head Up Display																																																											
Y	2004	ALL	Body	HVAC Control Module																																																											
Y	2004	ALL	Body	Instrument Panel Cluster																																																											
Y	2004	ALL	Body	Navigation Radio																																																											
Y	2004	ALL	Body	Passenger Door Module																																																											
Y	2004	ALL	Body	Remote Control Door Lock Receiver																																									V																		
Y	2004	ALL	Body	Steering Column Lock Module																																																											
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2005	ALL	Powertrain	Engine Control Module																																																											
Y	2005	ALL	Powertrain	Automatic Transmission																																																											
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2005	ALL	Chassis	Electronic Suspension Control																																																											
Y	2005	ALL	Chassis	Steering Wheel and Column																																																											
Y	2005	ALL	Body	Amplifier (Bose)																																																											
Y	2005	ALL	Body	Body Control Module															V			V	V				V	V																																			
Y	2005	ALL	Body	CD Changer																																																											
Y	2005	ALL	Body	Digital Radio Receiver																																																											
Y	2005	ALL	Body	Distance Sensing Cruise Control																																																											
Y	2005	ALL	Body	Driver Door Module																																																											
Y	2005	ALL	Body	Driver Door Switch																																																											
Y	2005	ALL	Body	Driver Position Module																																																											
Y	2005	ALL	Body	Folding Top Module																																																											
Y	2005	ALL	Body	Head Up Display																																																											
Y	2005	ALL	Body	HVAC Control Module																																																											
Y	2005	ALL	Body	Instrument Panel Cluster																																																											
Y	2005	ALL	Body	Navigation Radio																																																											
Y	2005	ALL	Body	Passenger Door Module																																																											
Y	2005	ALL	Body	Remote Control Door Lock Receiver																				V																						V																	
Y	2005	ALL	Body	Steering Column Lock Module																																																											
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2006	(YV)XLR	Powertrain	Engine Control Module																																																											
Y	2006	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																											
Y	2006	(YV)XLR	Powertrain	Automatic Transmission																																																											
Y	2006	(YV)XLR	Chassis	Electronic Brake Control Module																																																											
Y	2006	(YV)XLR	Chassis	Electronic Suspension Control																																																											
Y	2006	(YV)XLR	Chassis	Steering Wheel and Column																																																											
Y	2006	(YV)XLR	Body	Amplifier (Bose)																																																											
Y	2006	(YV)XLR	Body	Body Control Module															V			V	V				V	V																																			
Y	2006	(YV)XLR	Body	CD Changer																																																											
Y	2006	(YV)XLR	Body	Digital Radio Receiver																																																											
Y	2006	(YV)XLR	Body	Distance Sensing Cruise Control																																																											
Y	2006	(YV)XLR	Body	Driver Door Module																																																											
Y	2006	(YV)XLR	Body	Driver Door Switch																																																											
Y	2006	(YV)XLR	Body	Driver Position Module																																																											
Y	2006	(YV)XLR	Body	Folding Top Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Y	2006	(YV)XLR	Body	Headlamp Control Module																																																										
Y	2006	(YV)XLR	Body	Head Up Display																																																										
Y	2006	(YV)XLR	Body	HVAC Control Module																																																										
Y	2006	(YV)XLR	Body	Instrument Panel Cluster																																																										
Y	2006	(YV)XLR	Body	Navigation Radio																																																										
Y	2006	(YV)XLR	Body	Passenger Door Module																																																										
Y	2006	(YV)XLR	Body	Remote Control Door Lock Receiver																				V																					V																
Y	2006	(YV)XLR	Body	Steering Column Lock Module																																																										
Y	2006	(YV)XLR	Body	Supplemental Inflatable Restraint																																																										
Y	2006	(YX)XLR-V	Powertrain	Engine Control Module	V																																																									
Y	2006	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																										
Y	2006	(YX)XLR-V	Powertrain	Automatic Transmission		V	V																																																							
Y	2006	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																										
Y	2006	(YX)XLR-V	Chassis	Electronic Suspension Control																																																										
Y	2006	(YX)XLR-V	Chassis	Steering Wheel and Column																																																										
Y	2006	(YX)XLR-V	Body	Amplifier (Bose)																																																										
Y	2006	(YX)XLR-V	Body	Body Control Module															V			V	V				V	V																																		
Y	2006	(YX)XLR-V	Body	CD Changer																																																										
Y	2006	(YX)XLR-V	Body	Digital Radio Receiver																																																										
Y	2006	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																										
Y	2006	(YX)XLR-V	Body	Driver Door Module																																																										
Y	2006	(YX)XLR-V	Body	Driver Door Switch																																																										
Y	2006	(YX)XLR-V	Body	Driver Position Module																																																										
Y	2006	(YX)XLR-V	Body	Folding Top Module																																																										
Y	2006	(YX)XLR-V	Body	Headlamp Control Module																																																										
Y	2006	(YX)XLR-V	Body	Head Up Display																																																										
Y	2006	(YX)XLR-V	Body	HVAC Control Module																																																										
Y	2006	(YX)XLR-V	Body	Instrument Panel Cluster																																																										
Y	2006	(YX)XLR-V	Body	Navigation Radio																																																										
Y	2006	(YX)XLR-V	Body	Passenger Door Module																																																										
Y	2006	(YX)XLR-V	Body	Remote Control Door Lock Receiver																				V																					V																
Y	2006	(YX)XLR-V	Body	Steering Column Lock Module																																																										
Y	2006	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																										
Y	2007	(YV)XLR	Powertrain	Engine Control Module	V				V																																																					
Y	2007	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	(YV)XLR	Powertrain	Transmission Control Module		V																																																								
Y	2007	(YV)XLR	Chassis	Electronic Brake Control Module																																																										
Y	2007	(YV)XLR	Chassis	Electronic Suspension Control																																																										
Y	2007	(YV)XLR	Body	Amplifier (Bose)																																																										
Y	2007	(YV)XLR	Body	Body Control Module															V			V	V				V	V																																		
Y	2007	(YV)XLR	Body	CD Changer																																																										
Y	2007	(YV)XLR	Body	Digital Radio Receiver																																																										
Y	2007	(YV)XLR	Body	Distance Sensing Cruise Control																																																										
Y	2007	(YV)XLR	Body	Driver Door Module																																																										
Y	2007	(YV)XLR	Body	Driver Door Switch																																																										
Y	2007	(YV)XLR	Body	Driver Position Module																																																										
Y	2007	(YV)XLR	Body	Folding Top Module																																																										
Y	2007	(YV)XLR	Body	Headlamp Control Module																																																										
Y	2007	(YV)XLR	Body	Head Up Display																																																										
Y	2007	(YV)XLR	Body	HVAC Control Module																																																										
Y	2007	(YV)XLR	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Y	2007	(YV)XLR	Body	Navigation Radio																																																										
Y	2007	(YV)XLR	Body	Passenger Door Module																																																											
Y	2007	(YV)XLR	Body	Remote Control Door Lock Receiver																				V																						V																
Y	2007	(YV)XLR	Body	Steering Column Lock Module																																																										
Y	2007	(YV)XLR	Body	Supplemental Inflatable Restraint																																																										
Y	2007	(YX)XLR-V	Powertrain	Engine Control Module	V				V																																																					
Y	2007	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	(YX)XLR-V	Powertrain	Transmission Control Module		V																																																								
Y	2007	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																										
Y	2007	(YX)XLR-V	Chassis	Electronic Suspension Control																																																										
Y	2007	(YX)XLR-V	Body	Amplifier (Bose)																																																										
Y	2007	(YX)XLR-V	Body	Body Control Module															V			V	V				V	V																																		
Y	2007	(YX)XLR-V	Body	CD Changer																																																										
Y	2007	(YX)XLR-V	Body	Digital Radio Receiver																																																										
Y	2007	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																										
Y	2007	(YX)XLR-V	Body	Driver Door Module																																																										
Y	2007	(YX)XLR-V	Body	Driver Door Switch																																																										
Y	2007	(YX)XLR-V	Body	Driver Position Module																																																										
Y	2007	(YX)XLR-V	Body	Folding Top Module																																																										
Y	2007	(YX)XLR-V	Body	Headlamp Control Module																																																										
Y	2007	(YX)XLR-V	Body	Head Up Display																																																										
Y	2007	(YX)XLR-V	Body	HVAC Control Module																																																										
Y	2007	(YX)XLR-V	Body	Instrument Panel Cluster																																																										
Y	2007	(YX)XLR-V	Body	Navigation Radio																																																										
Y	2007	(YX)XLR-V	Body	Passenger Door Module																																																										
Y	2007	(YX)XLR-V	Body	Remote Control Door Lock Receiver																				V																						V																
Y	2007	(YX)XLR-V	Body	Steering Column Lock Module																																																										
Y	2007	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module	V																																																									
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module		V																																																								
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V																																																									
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module		V																																																								
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2008	ALL	Chassis	Electronic Suspension Control																																																										
Y	2008	ALL	Body	Amplifier (Bose)																																																										
Y	2008	ALL	Body	Body Control Module															V			V	V				V	V																																		
Y	2008	ALL	Body	CD Changer																																																										
Y	2008	ALL	Body	Digital Radio Receiver																																																										
Y	2008	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2008	ALL	Body	Driver Door Module																																																										
Y	2008	ALL	Body	Driver Door Switch																																																										
Y	2008	ALL	Body	Driver Position Module																																																										
Y	2008	ALL	Body	Folding Top Module																																																										
Y	2008	ALL	Body	Headlamp Control Module																																																										
Y	2008	ALL	Body	Head Up Display																																																										
Y	2008	ALL	Body	HVAC Control Module																																																										
Y	2008	ALL	Body	Instrument Panel Cluster																																																										
Y	2008	ALL	Body	Navigation Radio																																																										
Y	2008	ALL	Body	Passenger Door Module																																																										
Y	2008	ALL	Body	Remote Control Door Lock Receiver																				V																						V																

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Y	2008	ALL	Body	Steering Column Lock Module																																																										
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Body	Vehicle Comm. Interface Module																																																										
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module	V																																																									
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																										
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module		V																																																								
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V																																																									
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module		V																																																								
Y	2009	ALL	Chassis	Electronic Brake Control Module						V							V																																													
Y	2009	ALL	Chassis	Electronic Suspension Control																																																										
Y	2009	ALL	Body	Amplifier (Bose)																																																										
Y	2009	ALL	Body	Body Control Module															V			V	V				V	V																																		
Y	2009	ALL	Body	CD Changer																																																										
Y	2009	ALL	Body	Digital Radio Receiver																																																										
Y	2009	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2009	ALL	Body	Driver Door Module																																																										
Y	2009	ALL	Body	Driver Door Switch																																																										
Y	2009	ALL	Body	Driver Position Module																																																										
Y	2009	ALL	Body	Folding Top Module																																																										
Y	2009	ALL	Body	Headlamp Control Module																																																										
Y	2009	ALL	Body	Head Up Display																																																										
Y	2009	ALL	Body	HVAC Control Module																																																										
Y	2009	ALL	Body	Instrument Panel Cluster																																																										
Y	2009	ALL	Body	Navigation Radio																																																										
Y	2009	ALL	Body	Passenger Door Module																																																										
Y	2009	ALL	Body	Remote Control Door Lock Receiver																				V																					V																	
Y	2009	ALL	Body	Steering Column Lock Module																																																										
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
1	2013	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2013	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2013	XTS	Powertrain	Fuel Pump Control Module																																																										
1	2013	XTS	Powertrain	Rear Differential Clutch Control Module																																																										
1	2013	XTS	Chassis	Electronic Brake Control Module																																																										
1	2013	XTS	Chassis	Parking Brake Control Module																																																										
1	2013	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2013	XTS	Chassis	Power Steering Control Module																																																										
1	2013	XTS	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2013	XTS	Chassis	Suspension Control Module																																																										
1	2013	XTS	Body	Body Control Module																																																										
1	2013	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2013	XTS	Body	Passenger Presence Module																																																										
1	2013	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
1	2013	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
1	2013	XTS	Body	Radio/HVAC Control																																																										
1	2013	XTS	Body	Active Safety Control Module																																																										
1	2013	XTS	Body	Headlamp Control Module																																																										
1	2013	XTS	Body	Radio																																																										
1	2013	XTS	Body	Amplifier																																																										
1	2013	XTS	Body	Human Machine Interface Control Module																																																										
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2013	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2013	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
1	2013	XTS	Body	Seat Memory Control Module																																																											
1	2013	XTS	Body	Keyless Entry Control Module																																																											
1	2013	XTS	Body	Right Side Object Detection Control Module																																																											
1	2013	XTS	Body	Left Side Object Detection Control Module																																																											
1	2013	XTS	Body	Parking Assist Control Module																																																											
1	2013	XTS	Body	Frontview Camera Module																																																											
1	2013	XTS	Body	Long Range Radar Sensor Module																																																											
1	2013	XTS	Body	Left Front Short Range Radar Sensor Module																																																											
1	2013	XTS	Body	Right Front Short Range Radar Sensor Module																																																											
1	2013	XTS	Body	Rear Short Range Radar Sensor Module																																																											
1	2014	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
1	2014	XTS	Powertrain	(8) 3.6L LF3 Chassis Control Module																																																											
1	2014	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
1	2014	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2014	XTS	Powertrain	(3) 3.6L LFX Chassis Control Module																																																											
1	2014	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2014	XTS	Powertrain	Rear Differential Clutch Control Module																																																											
1	2014	XTS	Chassis	Electronic Brake Control Module																																																											
1	2014	XTS	Chassis	Parking Brake Control Module																																																											
1	2014	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2014	XTS	Chassis	Power Steering Control Module																																																											
1	2014	XTS	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	XTS	Chassis	Suspension Control Module																																																											
1	2014	XTS	Body	Body Control Module																																																											
1	2014	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	XTS	Body	Passenger Presence Module																																																											
1	2014	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
1	2014	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																											
1	2014	XTS	Body	Radio/HVAC Control																																																											
1	2014	XTS	Body	Active Safety Control Module																																																											
1	2014	XTS	Body	Headlamp Control Module																																																											
1	2014	XTS	Body	Radio																																																										
1	2014	XTS	Body	Amplifier																																																										
1	2014	XTS	Body	Media Disc Player																																																										
1	2014	XTS	Body	Human Machine Interface Control Module																																																											
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2014	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
1	2014	XTS	Body	Seat Memory Control Module - Passenger																																																											
1	2014	XTS	Body	Seat Memory Control Module - Driver																																																											
1	2014	XTS	Body	Keyless Entry Control Module																																																											
1	2014	XTS	Body	Right Side Object Detection Control Module																																																											
1	2014	XTS	Body	Left Side Object Detection Control Module																																																											
1	2014	XTS	Body	Parking Assist Control Module																																																											
1	2014	XTS	Body	Frontview Camera Module																																																											
1	2014	XTS	Body	Long Range Radar Sensor Module																																																											
1	2014	XTS	Body	Left Front Short Range Radar Sensor Module																																																											
1	2014	XTS	Body	Right Front Short Range Radar Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2014	XTS	Body	Rear Short Range Radar Sensor Module																																																										
1	2015	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
1	2015	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
1	2015	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2015	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2015	XTS	Powertrain	Chassis Control Module																																																										
1	2015	XTS	Powertrain	Rear Differential Clutch Control Module																																																										
1	2015	XTS	Chassis	Electronic Brake Control Module																																																										
1	2015	XTS	Chassis	Parking Brake Control Module																																																										
1	2015	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	XTS	Chassis	Power Steering Control Module																																																										
1	2015	XTS	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	XTS	Chassis	Suspension Control Module																																																										
1	2015	XTS	Body	Body Control Module																																																										
1	2015	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	XTS	Body	Passenger Presence Module																																																										
1	2015	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
1	2015	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
1	2015	XTS	Body	Radio/HVAC Control																																																										
1	2015	XTS	Body	Active Safety Control Module																																																										
1	2015	XTS	Body	Radio																																																										
1	2015	XTS	Body	Amplifier																																																									
1	2015	XTS	Body	Media Disc Player																																																									
1	2015	XTS	Body	Human Machine Interface Control Module																																																										
1	2015	XTS	Body	Telematics Communication Interface Control Module																																																										
1	2015	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2015	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
1	2015	XTS	Body	Seat Memory Control Module - Passenger																																																										
1	2015	XTS	Body	Seat Memory Control Module - Driver																																																										
1	2015	XTS	Body	Keyless Entry Control Module																																																										
1	2015	XTS	Body	Right Side Object Detection Control Module																																																										
1	2015	XTS	Body	Left Side Object Detection Control Module																																																										
1	2015	XTS	Body	Parking Assist Control Module GMLAN																																																										
1	2015	XTS	Body	Parking Assist Control Module DID72History																																																										
1	2015	XTS	Body	Frontview Camera Module																																																										
1	2015	XTS	Body	Long Range Radar Sensor Module																																																										
1	2015	XTS	Body	Left Front Short Range Radar Sensor Module																																																										
1	2015	XTS	Body	Right Front Short Range Radar Sensor Module																																																										
1	2015	XTS	Body	Rear Short Range Radar Sensor Module																																																										
1	2016	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
1	2016	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
1	2016	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2016	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2016	XTS	Powertrain	Chassis Control Module																																																										
1	2016	XTS	Powertrain	Rear Differential Clutch Control Module																																																										
1	2016	XTS	Chassis	Electronic Brake Control Module																																																										
1	2016	XTS	Chassis	Parking Brake Control Module																																																										
1	2016	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2016	XTS	Chassis	Power Steering Control Module																																																										
1	2016	XTS	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	XTS	Chassis	Suspension Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2016	XTS	Body	Body Control Module																																																											
1	2016	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2016	XTS	Body	Passenger Presence Module																																																												
1	2016	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
1	2016	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
1	2016	XTS	Body	Radio/HVAC Control																																																												
1	2016	XTS	Body	Active Safety Control Module																																																												
1	2016	XTS	Body	Video Processing Control Module																																																												
1	2016	XTS	Body	Radio																																																												
1	2016	XTS	Body	Amplifier																																																												
1	2016	XTS	Body	Media Disc Player																																																												
1	2016	XTS	Body	Human Machine Interface Control Module																																																												
1	2016	XTS	Body	Telematics Communication Interface Control Module																																																												
1	2016	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2016	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
1	2016	XTS	Body	Seat Memory Control Module - Passenger																																																												
1	2016	XTS	Body	Seat Memory Control Module - Driver																																																												
1	2016	XTS	Body	Keyless Entry Control Module																																																												
1	2016	XTS	Body	Right Side Object Detection Control Module																																																												
1	2016	XTS	Body	Left Side Object Detection Control Module																																																												
1	2016	XTS	Body	Parking Assist Control Module																																																												
1	2016	XTS	Body	Frontview Camera Module																																																												
1	2016	XTS	Body	Steering Column Lock Control Module																																																												
1	2016	XTS	Body	Long Range Radar Sensor Module																																																												
1	2016	XTS	Body	Left Front Short Range Radar Sensor Module																																																												
1	2016	XTS	Body	Right Front Short Range Radar Sensor Module																																																												
1	2016	XTS	Body	Rear Short Range Radar Sensor Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																												
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																												
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump																																																												
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Engine Mount																																																												
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2013	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
A	2013	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																												
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump																																																												
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Engine Mount																																																												
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2013	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump																																																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Engine Mount																																																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
A	2013	ATS	Powertrain	Transfer Case Control Module																																																													
A	2013	ATS	Chassis	Electronic Brake Control Module																																																												
A	2013	ATS	Chassis	Parking Brake Control Module																																																												
A	2013	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2013	ATS	Chassis	Power Steering Control Module																																																												
A	2013	ATS	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2013	ATS	Chassis	Suspension Control Module																																																												
A	2013	ATS	Body	Body Control Module Halogen																																																												
A	2013	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
A	2013	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2013	ATS	Body	Passenger Presence Module																																																												
A	2013	ATS	Body	Pedestrian Impact Detection Module																																																												
A	2013	ATS	Body	Instrument Cluster																																																												
A	2013	ATS	Body	Radio/HVAC Control																																																												
A	2013	ATS	Body	Active Safety Control Module																																																												
A	2013	ATS	Body	Headlamp Control Module																																																												
A	2013	ATS	Body	Trailer Interface Control Module																																																												
A	2013	ATS	Body	Radio																																																												
A	2013	ATS	Body	Amplifier																																																												
A	2013	ATS	Body	Human Machine Interface Control Module																																																												
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 9																																																												
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2013	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
A	2013	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
A	2013	ATS	Body	Seat Memory Control Module																																																												
A	2013	ATS	Body	Keyless Entry Type Without Passive Entry																																																												
A	2013	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																												
A	2013	ATS	Body	Right Side Object Detection Control Module																																																												
A	2013	ATS	Body	Left Side Object Detection Control Module																																																												
A	2013	ATS	Body	Parking Assist Control Module																																																												
A	2013	ATS	Body	Frontview Camera Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2013	ATS	Body	Steering Column Lock Control Module																																																												
A	2013	ATS	Body	Long Range Radar Sensor Module																																																												
A	2013	ATS	Body	Left Front Short Range Radar Sensor Module																																																												
A	2013	ATS	Body	Right Front Short Range Radar Sensor Module																																																												
A	2013	ATS	Body	Rear Short Range Radar Sensor Module																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Engine Control Module																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
A	2014	ATS	Powertrain	Transfer Case Control Module																																																													
A	2014	ATS	Chassis	Electronic Brake Control Module																																																												
A	2014	ATS	Chassis	Parking Brake Control Module																																																												
A	2014	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2014	ATS	Chassis	Power Steering Control Module																																																												
A	2014	ATS	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2014	ATS	Chassis	Suspension Control Module																																																												
A	2014	ATS	Body	Body Control Module Halogen																																																												
A	2014	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
A	2014	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2014	ATS	Body	Passenger Presence Module																																																												
A	2014	ATS	Body	Pedestrian Impact Detection Module																																																												
A	2014	ATS	Body	Instrument Cluster																																																												
A	2014	ATS	Body	Radio/HVAC Control																																																												
A	2014	ATS	Body	Active Safety Control Module																																																												
A	2014	ATS	Body	Headlamp Control Module																																																												
A	2014	ATS	Body	Trailer Interface Control Module																																																												
A	2014	ATS	Body	Radio																																																												
A	2014	ATS	Body	Amplifier																																																												
A	2014	ATS	Body	Media Disc Player																																																												
A	2014	ATS	Body	Human Machine Interface Control Module																																																												
A	2014	ATS	Body	Navigation Control Module																																																												
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 9																																																												
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2014	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
A	2014	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
A	2014	ATS	Body	Seat Memory Control Module - Driver																																																												
A	2014	ATS	Body	Keyless Entry Type Without Passive Entry																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2014	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																													
A	2014	ATS	Body	Right Side Object Detection Control Module																																																													
A	2014	ATS	Body	Left Side Object Detection Control Module																																																												
A	2014	ATS	Body	Parking Assist Control Module																																																												
A	2014	ATS	Body	Frontview Camera Module																																																												
A	2014	ATS	Body	Steering Column Lock Control Module																																																												
A	2014	ATS	Body	Long Range Radar Sensor Module																																																												
A	2014	ATS	Body	Left Front Short Range Radar Sensor Module																																																												
A	2014	ATS	Body	Right Front Short Range Radar Sensor Module																																																												
A	2014	ATS	Body	Rear Short Range Radar Sensor Module																																																												
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																												
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Maunal Transmission																																																												
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
A	2014	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																												
A	2014	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																												
A	2014	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																												
A	2014	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																												
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																												
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																												
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	CTS	Powertrain	Transfer Case Control Module																																																													
A	2014	CTS	Chassis	Electronic Brake Control Module																																																													
A	2014	CTS	Chassis	Parking Brake Control Module																																																													
A	2014	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																													
A	2014	CTS	Chassis	Power Steering Control Module																																																													
A	2014	CTS	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2014	CTS	Chassis	Suspension Control Module																																																													
A	2014	CTS	Body	Body Control Module Headlamp Type Halogen																																																													
A	2014	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
A	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2014	CTS	Body	Passenger Presence Module																																																													
A	2014	CTS	Body	Pedestrian Impact Detection Module																																																													
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Left																																																													
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Right																																																													
A	2014	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																													
A	2014	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																													
A	2014	CTS	Body	Radio/HVAC Control																																																													
A	2014	CTS	Body	Active Safety Control Module																																																													
A	2014	CTS	Body	Headlamp Control Module																																																													
A	2014	CTS	Body	Trailer Interface Control Module																																																													
A	2014	CTS	Body	Radio																																																													
A	2014	CTS	Body	Amplifier																																																													
A	2014	CTS	Body	Human Machine Interface Control Module																																																													
A	2014	CTS	Body	Navigation Control Module																																																													
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																													
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2014	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
A	2014	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																													
A	2014	CTS	Body	Seat Memory Control Module - Driver																																																													
A	2014	CTS	Body	Keyless Entry Control Module																																																													
A	2014	CTS	Body	Right Side Object Detection Control Module																																																													
A	2014	CTS	Body	Left Side Object Detection Control Module																																																													
A	2014	CTS	Body	Parking Assist Control Module																																																													
A	2014	CTS	Body	Frontview Camera Module																																																													
A	2014	CTS	Body	Steering Column Lock Control Module																																																													
A	2014	CTS	Body	Long Range Radar Sensor Module																																																													
A	2014	CTS	Body	Left Front Short Range Radar Sensor Module																																																													
A	2014	CTS	Body	Right Front Short Range Radar Sensor Module																																																													
A	2014	CTS	Body	Rear Short Range Radar Sensor Module																																																													
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																													
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																													
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																													
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																													
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																													
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																													
A	2015	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																													
A	2015	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																													
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																													
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																													
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																													
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																													
A	2015	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																													
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																													
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																													
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																													
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																													
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																													
A	2015	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
A	2015	ATS	Powertrain	Transfer Case Control Module																																																														
A	2015	ATS	Chassis	Electronic Brake Control Module																																																													
A	2015	ATS	Chassis	Parking Brake Control Module																																																													
A	2015	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																													
A	2015	ATS	Chassis	Power Steering Control Module																																																													
A	2015	ATS	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2015	ATS	Chassis	Suspension Control Module																																																													
A	2015	ATS	Body	Body Control Module Halogen																																																													
A	2015	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
A	2015	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2015	ATS	Body	Passenger Presence Module																																																													
A	2015	ATS	Body	Pedestrian Impact Detection Module																																																													
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Left																																																													
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Right																																																													
A	2015	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																													
A	2015	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																													
A	2015	ATS	Body	Radio/HVAC Control																																																													
A	2015	ATS	Body	Active Safety Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2015	ATS	Body	Headlamp Control Module																																																													
A	2015	ATS	Body	Trailer Interface Control Module																																																													
A	2015	ATS	Body	Radio																																																												
A	2015	ATS	Body	Amplifier																																																												
A	2015	ATS	Body	Media Disc Player																																																												
A	2015	ATS	Body	Human Machine Interface Control Module																																																												
A	2015	ATS	Body	Navigation Control Module																																																												
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																												
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2015	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
A	2015	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
A	2015	ATS	Body	Seat Memory Control Module - Driver																																																												
A	2015	ATS	Body	Keyless Entry Control Module Coupe																																																												
A	2015	ATS	Body	Keyless Entry Control Module Sadan																																																												
A	2015	ATS	Body	Right Side Object Detection Control Module																																																												
A	2015	ATS	Body	Left Side Object Detection Control Module																																																												
A	2015	ATS	Body	Parking Assist Control Module																																																												
A	2015	ATS	Body	Frontview Camera Module																																																												
A	2015	ATS	Body	Steering Column Lock Control Module																																																												
A	2015	ATS	Body	Long Range Radar Sensor Module																																																												
A	2015	ATS	Body	Left Front Short Range Radar Sensor Module																																																												
A	2015	ATS	Body	Right Front Short Range Radar Sensor Module																																																												
A	2015	ATS	Body	Rear Short Range Radar Sensor Module																																																												
A	2015	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																												
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Engine Mount																																																												
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2015	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
A	2015	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																												
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																												
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2015	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																												
A	2015	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																												
A	2015	CTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Engine Mount																																																												
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																												
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																												
A	2015	CTS	Powertrain	Transfer Case Control Module																																																												
A	2015	CTS	Chassis	Electronic Brake Control Module																																																												
A	2015	CTS	Chassis	Parking Brake Control Module																																																												
A	2015	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2015	CTS	Chassis	Power Steering Control Module																																																												
A	2015	CTS	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2015	CTS	Chassis	Suspension Control Module																																																												
A	2015	CTS	Body	Body Control Module Headlamp Type Halogen																																																												
A	2015	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
A	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2015	CTS	Body	Passenger Presence Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2015	CTS	Body	Pedestrian Impact Detection Module																																																													
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Left																																																													
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Right																																																													
A	2015	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																													
A	2015	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																													
A	2015	CTS	Body	Active Safety Control Module																																																													
A	2015	CTS	Body	Trailer Interface Control Module																																																													
A	2015	CTS	Body	Radio																																																												
A	2015	CTS	Body	Amplifier																																																												
A	2015	CTS	Body	Human Machine Interface Control Module																																																												
A	2015	CTS	Body	Navigation Control Module																																																												
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																												
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2015	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
A	2015	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
A	2015	CTS	Body	Seat Memory Control Module - Driver																																																												
A	2015	CTS	Body	Keyless Entry Control Module																																																												
A	2015	CTS	Body	Right Side Object Detection Control Module																																																												
A	2015	CTS	Body	Left Side Object Detection Control Module																																																												
A	2015	CTS	Body	Parking Assist Control Module																																																												
A	2015	CTS	Body	Frontview Camera Module																																																												
A	2015	CTS	Body	Steering Column Lock Control Module																																																												
A	2015	CTS	Body	Long Range Radar Sensor Module																																																												
A	2015	CTS	Body	Left Front Short Range Radar Sensor Module																																																												
A	2015	CTS	Body	Right Front Short Range Radar Sensor Module																																																												
A	2015	CTS	Body	Rear Short Range Radar Sensor Module																																																												
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																												
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																												
A	2016	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
A	2016	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Automatic Transmission																																																												
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Manual Transmission																																																												
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Transmission Control Module																																																												
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																												
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																												
A	2016	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
A	2016	ATS	Powertrain	Transfer Case Control Module																																																												
A	2016	ATS	Powertrain	Rear Differential Clutch Control Module																																																												
A	2016	ATS	Chassis	Electronic Brake Control Module																																																												
A	2016	ATS	Chassis	Parking Brake Control Module																																																												
A	2016	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2016	ATS	Chassis	Power Steering Control Module																																																												
A	2016	ATS	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2016	ATS	Chassis	Suspension Control Module																																																												
A	2016	ATS	Body	Body Control Module Halogen																																																												
A	2016	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
A	2016	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2016	ATS	Body	Passenger Presence Module																																																												
A	2016	ATS	Body	Pedestrian Impact Detection Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Left																																																															
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Right																																																															
A	2016	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																															
A	2016	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																															
A	2016	ATS	Body	Radio/HVAC Control																																																															
A	2016	ATS	Body	Vehicle Performance Data Recorder																																																															
A	2016	ATS	Body	Trailer Interface Control Module																																																															
A	2016	ATS	Body	Radio																																																															
A	2016	ATS	Body	Amplifier																																																															
A	2016	ATS	Body	Rear Audio Control Module																																																															
A	2016	ATS	Body	Media Disc Player																																																															
A	2016	ATS	Body	Human Machine Interface Control Module																																																															
A	2016	ATS	Body	Navigation Control Module																																																															
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																															
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 10																																																															
A	2016	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
A	2016	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																															
A	2016	ATS	Body	Seat Memory Control Module - Passenger																																																															
A	2016	ATS	Body	Seat Memory Control Module - Driver																																																															
A	2016	ATS	Body	Keyless Entry Control Module Coupe																																																															
A	2016	ATS	Body	Keyless Entry Control Module Sadan																																																															
A	2016	ATS	Body	Right Side Object Detection Control Module																																																															
A	2016	ATS	Body	Left Side Object Detection Control Module																																																															
A	2016	ATS	Body	Parking Assist Control Module																																																															
A	2016	ATS	Body	Frontview Camera Module																																																															
A	2016	ATS	Body	Steering Column Lock Control Module																																																															
A	2016	ATS	Body	Long Range Radar Sensor Module																																																															
A	2016	ATS	Body	Left Front Short Range Radar Sensor Module																																																															
A	2016	ATS	Body	Right Front Short Range Radar Sensor Module																																																															
A	2016	ATS	Body	Rear Short Range Radar Sensor Module																																																															
A	2016	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																															
A	2016	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																															
A	2016	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																															
A	2016	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																															
A	2016	CTS	Powertrain	(S) 3.6L LGX Engine Control Module																																																															
A	2016	CTS	Powertrain	(S) 3.6L LGX Transmission Control Module																																																															
A	2016	CTS	Powertrain	(6) 6.2L LT4 Engine Control Module																																																															
A	2016	CTS	Powertrain	(6) 6.2L LT4 Transmission Control Module																																																															
A	2016	CTS	Powertrain	Rear Differential Clutch Control Module																																																															
A	2016	CTS	Powertrain	Transfer Case Control Module																																																															
A	2016	CTS	Chassis	Electronic Brake Control Module																																																															
A	2016	CTS	Chassis	Parking Brake Control Module																																																															
A	2016	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																															
A	2016	CTS	Chassis	Power Steering Control Module																																																															
A	2016	CTS	Chassis	Steering Wheel Angle Sensor Module																																																															
A	2016	CTS	Chassis	Suspension Control Module																																																															
A	2016	CTS	Body	Body Control Module Headlamp Type Halogen																																																															
A	2016	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																															
A	2016	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
A	2016	CTS	Body	Passenger Presence Module																																																															
A	2016	CTS	Body	Pedestrian Impact Detection Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Left																																																														
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Right																																																														
A	2016	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																														
A	2016	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																														
A	2016	CTS	Body	Radio/HVAC Control																																																														
A	2016	CTS	Body	Vehicle Performance Data Recorder																																																														
A	2016	CTS	Body	Active Safety Control Module																																																														
A	2016	CTS	Body	Video Processing Control Module																																																														
A	2016	CTS	Body	Trailer Interface Control Module																																																														
A	2016	CTS	Body	Radio																																																														
A	2016	CTS	Body	Amplifier																																																														
A	2016	CTS	Body	Human Machine Interface Control Module																																																														
A	2016	CTS	Body	Navigation Control Module																																																														
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																														
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 10																																																														
A	2016	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
A	2016	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																														
A	2016	CTS	Body	Seat Memory Control Module - Passenger																																																														
A	2016	CTS	Body	Seat Memory Control Module - Driver																																																														
A	2016	CTS	Body	Keyless Entry Control Module																																																														
A	2016	CTS	Body	Right Side Object Detection Control Module																																																														
A	2016	CTS	Body	Left Side Object Detection Control Module																																																														
A	2016	CTS	Body	Parking Assist Control Module																																																														
A	2016	CTS	Body	Frontview Camera Module																																																														
A	2016	CTS	Body	Steering Column Lock Control Module																																																														
A	2016	CTS	Body	Long Range Radar Sensor Module																																																														
A	2016	CTS	Body	Left Front Short Range Radar Sensor Module																																																														
A	2016	CTS	Body	Right Front Short Range Radar Sensor Module																																																														
A	2016	CTS	Body	Rear Short Range Radar Sensor Module																																																														
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																														
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																														
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																														
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																														
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																														
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																														
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																														
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
D	2004	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																														
D	2004	(DM)CTS	Chassis	VES																																																														
D	2004	(DM)CTS	Body	Amplifier (Bose)																																																														
D	2004	(DM)CTS	Body	Amplifier (Delco)																																																														
D	2004	(DM)CTS	Body	Climate Control Panel																																																														
D	2004	(DM)CTS	Body	Dash Integration Module																																																														
D	2004	(DM)CTS	Body	Digital Radio Receiver																																																														
D	2004	(DM)CTS	Body	Driver Door Switch																																																														
D	2004	(DM)CTS	Body	Driver Door Module																																																														
D	2004	(DM)CTS	Body	Passenger Door Module																																																														
D	2004	(DM)CTS	Body	Left Rear Door Module																																																														
D	2004	(DM)CTS	Body	Right Rear Door Module																																																														
D	2004	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																														
D	2004	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2004	(DM)CTS	Body	Instrument Panel Cluster																																																											
D	2004	(DM)CTS	Body	Memory Seat Module																																																												
D	2004	(DM)CTS	Body	Personalization																																																												
D	2004	(DM)CTS	Body	Rear Integration Module																																																												
D	2004	(DM)CTS	Body	Remote Function Actuation																																																												
D	2004	(DM)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2004	(DM)CTS	Body	TV Antenna Module																																																												
D	2004	(DM)CTS	Body	Vehicle Theft Deterrent																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																												
D	2004	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2004	(DR)CTS	Chassis	VES																																																												
D	2004	(DR)CTS	Body	Amplifier (Bose)																																																												
D	2004	(DR)CTS	Body	Amplifier (Delco)																																																												
D	2004	(DR)CTS	Body	Climate Control Panel																																																												
D	2004	(DR)CTS	Body	Dash Integration Module																																																												
D	2004	(DR)CTS	Body	Digital Radio Receiver																																																												
D	2004	(DR)CTS	Body	Driver Door Switch																																																												
D	2004	(DR)CTS	Body	Driver Door Module																																																												
D	2004	(DR)CTS	Body	Passenger Door Module																																																												
D	2004	(DR)CTS	Body	Left Rear Door Module																																																												
D	2004	(DR)CTS	Body	Right Rear Door Module																																																												
D	2004	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2004	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2004	(DR)CTS	Body	Instrument Panel Cluster																																																												
D	2004	(DR)CTS	Body	Memory Seat Module																																																												
D	2004	(DR)CTS	Body	Personalization																																																												
D	2004	(DR)CTS	Body	Rear Integration Module																																																												
D	2004	(DR)CTS	Body	Remote Function Actuation																																																												
D	2004	(DR)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2004	(DR)CTS	Body	TV Antenna Module																																																												
D	2004	(DR)CTS	Body	Vehicle Theft Deterrent																																																												
D	2004	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																												
D	2004	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																												
D	2004	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																												
D	2004	(DN)CTS-V	Chassis	VES																																																												
D	2004	(DN)CTS-V	Body	Amplifier (Bose)																																																												
D	2004	(DN)CTS-V	Body	Amplifier (Delco)																																																												
D	2004	(DN)CTS-V	Body	Climate Control Panel																																																												
D	2004	(DN)CTS-V	Body	Dash Integration Module																																																												
D	2004	(DN)CTS-V	Body	Digital Radio Receiver																																																												
D	2004	(DN)CTS-V	Body	Driver Door Switch																																																												
D	2004	(DN)CTS-V	Body	Driver Door Module																																																												
D	2004	(DN)CTS-V	Body	Passenger Door Module																																																												
D	2004	(DN)CTS-V	Body	Left Rear Door Module																																																												
D	2004	(DN)CTS-V	Body	Right Rear Door Module																																																												
D	2004	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2004	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																												
D	2004	(DN)CTS-V	Body	Instrument Panel Cluster																																																												
D	2004	(DN)CTS-V	Body	Memory Seat Module																																																												
D	2004	(DN)CTS-V	Body	Personalization																																																												
D	2004	(DN)CTS-V	Body	Rear Integration Module																																																												
D	2004	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																												
D	2004	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																												
D	2004	(DN)CTS-V	Body	TV Antenna Module																																																												
D	2004	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																												
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																												
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2005	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2005	(DM)CTS	Chassis	VES																																																												
D	2005	(DM)CTS	Body	Amplifier (Bose)																																																												
D	2005	(DM)CTS	Body	Amplifier (Delco)																																																												
D	2005	(DM)CTS	Body	Climate Control Panel																																																												
D	2005	(DM)CTS	Body	Dash Integration Module																																																												
D	2005	(DM)CTS	Body	Digital Radio Receiver																																																												
D	2005	(DM)CTS	Body	Driver Door Switch																																																												
D	2005	(DM)CTS	Body	Driver Door Module																																																												
D	2005	(DM)CTS	Body	Passenger Door Module																																																												
D	2005	(DM)CTS	Body	Left Rear Door Module																																																												
D	2005	(DM)CTS	Body	Right Rear Door Module																																																												
D	2005	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2005	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2005	(DM)CTS	Body	Instrument Panel Cluster																																																												
D	2005	(DM)CTS	Body	Memory Seat Module																																																												
D	2005	(DM)CTS	Body	Personalization																																																												
D	2005	(DM)CTS	Body	Rear Integration Module																																																												
D	2005	(DM)CTS	Body	Remote Control Door Lock Receiver																																																												
D	2005	(DM)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2005	(DM)CTS	Body	TV Antenna Module																																																												
D	2005	(DM)CTS	Body	Vehicle Theft Deterrent																																																												
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																												
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2005	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2005	(DP)CTS	Chassis	VES																																																												
D	2005	(DP)CTS	Body	Amplifier (Bose)																																																												
D	2005	(DP)CTS	Body	Amplifier (Delco)																																																												
D	2005	(DP)CTS	Body	Climate Control Panel																																																												
D	2005	(DP)CTS	Body	Dash Integration Module																																																												
D	2005	(DP)CTS	Body	Digital Radio Receiver																																																												
D	2005	(DP)CTS	Body	Driver Door Switch																																																												
D	2005	(DP)CTS	Body	Driver Door Module																																																												
D	2005	(DP)CTS	Body	Passenger Door Module																																																												
D	2005	(DP)CTS	Body	Left Rear Door Module																																																												
D	2005	(DP)CTS	Body	Right Rear Door Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2005	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2005	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2005	(DP)CTS	Body	Instrument Panel Cluster																																																											
D	2005	(DP)CTS	Body	Memory Seat Module																																																											
D	2005	(DP)CTS	Body	Personalization																																																											
D	2005	(DP)CTS	Body	Rear Integration Module																																																											
D	2005	(DP)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DP)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2005	(DP)CTS	Body	TV Antenna Module																																																											
D	2005	(DP)CTS	Body	Vehicle Theft Deterrent																																																											
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2005	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2005	(DR)CTS	Chassis	VES																																																											
D	2005	(DR)CTS	Body	Amplifier (Bose)																																																											
D	2005	(DR)CTS	Body	Amplifier (Delco)																																																											
D	2005	(DR)CTS	Body	Climate Control Panel																																																											
D	2005	(DR)CTS	Body	Dash Integration Module																																																											
D	2005	(DR)CTS	Body	Digital Radio Receiver																																																											
D	2005	(DR)CTS	Body	Driver Door Switch																																																											
D	2005	(DR)CTS	Body	Driver Door Module																																																											
D	2005	(DR)CTS	Body	Passenger Door Module																																																											
D	2005	(DR)CTS	Body	Left Rear Door Module																																																											
D	2005	(DR)CTS	Body	Right Rear Door Module																																																											
D	2005	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2005	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2005	(DR)CTS	Body	Instrument Panel Cluster																																																											
D	2005	(DR)CTS	Body	Memory Seat Module																																																											
D	2005	(DR)CTS	Body	Personalization																																																											
D	2005	(DR)CTS	Body	Radio																																																											
D	2005	(DR)CTS	Body	Rear Integration Module																																																											
D	2005	(DR)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DR)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2005	(DR)CTS	Body	TV Antenna Module																																																											
D	2005	(DR)CTS	Body	Vehicle Theft Deterrent																																																											
D	2005	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																											
D	2005	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																											
D	2005	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																											
D	2005	(DN)CTS-V	Chassis	VES																																																											
D	2005	(DN)CTS-V	Body	Amplifier (Bose)																																																											
D	2005	(DN)CTS-V	Body	Amplifier (Delco)																																																											
D	2005	(DN)CTS-V	Body	Climate Control Panel																																																											
D	2005	(DN)CTS-V	Body	Dash Integration Module																																																											
D	2005	(DN)CTS-V	Body	Digital Radio Receiver																																																											
D	2005	(DN)CTS-V	Body	Driver Door Switch																																																											
D	2005	(DN)CTS-V	Body	Driver Door Module																																																											
D	2005	(DN)CTS-V	Body	Passenger Door Module																																																											
D	2005	(DN)CTS-V	Body	Left Rear Door Module																																																											
D	2005	(DN)CTS-V	Body	Right Rear Door Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2005	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																														
D	2005	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																														
D	2005	(DN)CTS-V	Body	Instrument Panel Cluster																																																														
D	2005	(DN)CTS-V	Body	Memory Seat Module																																																														
D	2005	(DN)CTS-V	Body	Personalization																																																														
D	2005	(DN)CTS-V	Body	Radio																																																														
D	2005	(DN)CTS-V	Body	Rear Integration Module																																																														
D	2005	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																														
D	2005	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																													
D	2005	(DN)CTS-V	Body	TV Antenna Module																																																													
D	2005	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																													
D	2005	(DC)STS-V8	Powertrain	Engine Control Module																																																													
D	2005	(DC)STS-V8	Powertrain	Transmission Control Module																																																													
D	2005	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																													
D	2005	(DC)STS-V8	Chassis	Electronic Suspension Control																																																													
D	2005	(DC)STS-V8	Body	Amplifier (Bose)																																																													
D	2005	(DC)STS-V8	Body	Digital Radio Receiver																																																													
D	2005	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																													
D	2005	(DC)STS-V8	Body	Driver Door Module																																																													
D	2005	(DC)STS-V8	Body	Driver Door Switch																																																													
D	2005	(DC)STS-V8	Body	Driver Position Module																																																													
D	2005	(DC)STS-V8	Body	Headlamp Control Module																																																													
D	2005	(DC)STS-V8	Body	Head Up Display																																																													
D	2005	(DC)STS-V8	Body	HVAC Control Module																																																													
D	2005	(DC)STS-V8	Body	Instrument Panel Cluster																																																													
D	2005	(DC)STS-V8	Body	Instrument Panel Module																																																													
D	2005	(DC)STS-V8	Body	Left Rear Door Module																																																													
D	2005	(DC)STS-V8	Body	Passenger Door Module																																																													
D	2005	(DC)STS-V8	Body	Uplevel Radio																																																													
D	2005	(DC)STS-V8	Body	Navigation Radio																																																													
D	2005	(DC)STS-V8	Body	Rear Integration Module																																																													
D	2005	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																													
D	2005	(DC)STS-V8	Body	Right Rear Door Module																																																													
D	2005	(DC)STS-V8	Body	Steering Column Lock Module																																																													
D	2005	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																													
D	2005	(DC)STS-V8	Body	TV Antenna Module																																																													
D	2005	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																													
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
D	2005	(DW)STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																													
D	2005	(DW)STS	Chassis	Electronic Brake Control Module																																																													
D	2005	(DW)STS	Chassis	Electronic Suspension Control																																																													
D	2005	(DW)STS	Body	Amplifier (Bose)																																																													
D	2005	(DW)STS	Body	Digital Radio Receiver																																																													
D	2005	(DW)STS	Body	Distance Sensing Cruise Control																																																													
D	2005	(DW)STS	Body	Driver Door Module																																																													
D	2005	(DW)STS	Body	Driver Door Switch																																																													
D	2005	(DW)STS	Body	Driver Position Module																																																													
D	2005	(DW)STS	Body	Headlamp Control Module																																																													
D	2005	(DW)STS	Body	Head Up Display																																																													
D	2005	(DW)STS	Body	HVAC Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2005	(DW)STS	Body	Instrument Panel Cluster																																																														
D	2005	(DW)STS	Body	Instrument Panel Module																																																														
D	2005	(DW)STS	Body	Left Rear Door Module																																																													
D	2005	(DW)STS	Body	Passenger Door Module																																																													
D	2005	(DW)STS	Body	Uplevel Radio																																																													
D	2005	(DW)STS	Body	Navigation Radio																																																													
D	2005	(DW)STS	Body	Rear Integration Module																																																													
D	2005	(DW)STS	Body	Remote Control Door Lock Receiver																																																													
D	2005	(DW)STS	Body	Right Rear Door Module																																																													
D	2005	(DW)STS	Body	Steering Column Lock Module																																																													
D	2005	(DW)STS	Body	Supplemental Inflatable Restraint																																																													
D	2005	(DW)STS	Body	TV Antenna Module																																																													
D	2005	(DW)STS	Body	Vehicle Comm. Interface Module																																																													
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																													
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																													
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
D	2006	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																													
D	2006	(DM)CTS	Chassis	Tire Pressure Monitor																																																													
D	2006	(DM)CTS	Chassis	VES																																																													
D	2006	(DM)CTS	Body	Amplifier (Bose)																																																													
D	2006	(DM)CTS	Body	Amplifier (Delco)																																																													
D	2006	(DM)CTS	Body	Climate Control Panel																																																													
D	2006	(DM)CTS	Body	Dash Integration Module																																																													
D	2006	(DM)CTS	Body	Digital Radio Receiver																																																													
D	2006	(DM)CTS	Body	Driver Door Switch																																																													
D	2006	(DM)CTS	Body	Driver Door Module																																																													
D	2006	(DM)CTS	Body	Passenger Door Module																																																													
D	2006	(DM)CTS	Body	Left Rear Door Module																																																													
D	2006	(DM)CTS	Body	Right Rear Door Module																																																													
D	2006	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																													
D	2006	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																													
D	2006	(DM)CTS	Body	Instrument Panel Cluster																																																													
D	2006	(DM)CTS	Body	Memory Seat Module																																																													
D	2006	(DM)CTS	Body	Personalization																																																													
D	2006	(DM)CTS	Body	Radio																																																													
D	2006	(DM)CTS	Body	Rear Integration Module																																																													
D	2006	(DM)CTS	Body	Remote Control Door Lock Receiver																																																													
D	2006	(DM)CTS	Body	Supplemental Inflatable Restraint																																																													
D	2006	(DM)CTS	Body	TV Antenna Module																																																													
D	2006	(DM)CTS	Body	Vehicle Theft Deterrent																																																													
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																													
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																													
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
D	2006	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																													
D	2006	(DP)CTS	Chassis	Tire Pressure Monitor																																																													
D	2006	(DP)CTS	Chassis	VES																																																													
D	2006	(DP)CTS	Body	Amplifier (Bose)																																																													
D	2006	(DP)CTS	Body	Amplifier (Delco)																																																													
D	2006	(DP)CTS	Body	Climate Control Panel																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2006	(DP)CTS	Body	Dash Integration Module																																																											
D	2006	(DP)CTS	Body	Digital Radio Receiver																																																											
D	2006	(DP)CTS	Body	Driver Door Switch																																																											
D	2006	(DP)CTS	Body	Driver Door Module																																																											
D	2006	(DP)CTS	Body	Passenger Door Module																																																											
D	2006	(DP)CTS	Body	Left Rear Door Module																																																											
D	2006	(DP)CTS	Body	Right Rear Door Module																																																											
D	2006	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DP)CTS	Body	Instrument Panel Cluster																																																											
D	2006	(DP)CTS	Body	Memory Seat Module																																																											
D	2006	(DP)CTS	Body	Personalization																																																											
D	2006	(DP)CTS	Body	Radio																																																											
D	2006	(DP)CTS	Body	Rear Integration Module																																																											
D	2006	(DP)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DP)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DP)CTS	Body	TV Antenna Module																																																											
D	2006	(DP)CTS	Body	Vehicle Theft Deterrent																																																											
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DR)CTS	Chassis	Tire Pressure Monitor																																																											
D	2006	(DR)CTS	Chassis	VES																																																											
D	2006	(DR)CTS	Body	Amplifier (Bose)																																																											
D	2006	(DR)CTS	Body	Amplifier (Delco)																																																											
D	2006	(DR)CTS	Body	Climate Control Panel																																																											
D	2006	(DR)CTS	Body	Dash Integration Module																																																											
D	2006	(DR)CTS	Body	Digital Radio Receiver																																																											
D	2006	(DR)CTS	Body	Driver Door Switch																																																											
D	2006	(DR)CTS	Body	Driver Door Module																																																											
D	2006	(DR)CTS	Body	Passenger Door Module																																																											
D	2006	(DR)CTS	Body	Left Rear Door Module																																																											
D	2006	(DR)CTS	Body	Right Rear Door Module																																																											
D	2006	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DR)CTS	Body	Instrument Panel Cluster																																																											
D	2006	(DR)CTS	Body	Memory Seat Module																																																											
D	2006	(DR)CTS	Body	Personalization																																																											
D	2006	(DR)CTS	Body	Radio																																																											
D	2006	(DR)CTS	Body	Rear Integration Module																																																											
D	2006	(DR)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DR)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DR)CTS	Body	TV Antenna Module																																																											
D	2006	(DR)CTS	Body	Vehicle Theft Deterrent																																																											
D	2006	(DN)CTS-V	Powertrain	Engine Control Module																																																											
D	2006	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																											
D	2006	(DN)CTS-V	Chassis	VES																																																											
D	2006	(DN)CTS-V	Body	Amplifier (Bose)																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2006	(DN)CTS-V	Body	Amplifier (Delco)																																																														
D	2006	(DN)CTS-V	Body	Climate Control Panel																																																														
D	2006	(DN)CTS-V	Body	Dash Integration Module																																																														
D	2006	(DN)CTS-V	Body	Digital Radio Receiver																																																														
D	2006	(DN)CTS-V	Body	Driver Door Switch																																																														
D	2006	(DN)CTS-V	Body	Driver Door Module																																																														
D	2006	(DN)CTS-V	Body	Passenger Door Module																																																														
D	2006	(DN)CTS-V	Body	Left Rear Door Module																																																														
D	2006	(DN)CTS-V	Body	Right Rear Door Module																																																														
D	2006	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																														
D	2006	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																														
D	2006	(DN)CTS-V	Body	Instrument Panel Cluster																																																														
D	2006	(DN)CTS-V	Body	Memory Seat Module																																																														
D	2006	(DN)CTS-V	Body	Personalization																																																														
D	2006	(DN)CTS-V	Body	Rear Integration Module																																																														
D	2006	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																														
D	2006	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																														
D	2006	(DN)CTS-V	Body	TV Antenna Module																																																														
D	2006	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																														
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Engine Controls																																																														
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																														
D	2006	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																														
D	2006	(DC)STS-V8	Chassis	Electronic Suspension Control																																																														
D	2006	(DC)STS-V8	Body	Amplifier (Bose)																																																														
D	2006	(DC)STS-V8	Body	Digital Radio Receiver																																																														
D	2006	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																														
D	2006	(DC)STS-V8	Body	Driver Door Module																																																														
D	2006	(DC)STS-V8	Body	Driver Door Switch																																																														
D	2006	(DC)STS-V8	Body	Driver Position Module																																																														
D	2006	(DC)STS-V8	Body	Headlamp Control Module																																																														
D	2006	(DC)STS-V8	Body	Head Up Display																																																														
D	2006	(DC)STS-V8	Body	HVAC Control Module																																																														
D	2006	(DC)STS-V8	Body	Instrument Panel Cluster																																																														
D	2006	(DC)STS-V8	Body	Instrument Panel Module																																																														
D	2006	(DC)STS-V8	Body	Left Rear Door Module																																																														
D	2006	(DC)STS-V8	Body	Passenger Door Module																																																														
D	2006	(DC)STS-V8	Body	Uplevel Radio																																																														
D	2006	(DC)STS-V8	Body	Navigation Radio																																																														
D	2006	(DC)STS-V8	Body	Rear Integration Module																																																														
D	2006	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																														
D	2006	(DC)STS-V8	Body	Right Rear Door Module																																																														
D	2006	(DC)STS-V8	Body	Steering Column Lock Module																																																														
D	2006	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																														
D	2006	(DC)STS-V8	Body	TV Antenna Module																																																														
D	2006	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																														
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																														
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
D	2006	(DW)STS	Chassis	Electronic Brake Control Module																																																														
D	2006	(DW)STS	Chassis	Electronic Suspension Control																																																														
D	2006	(DW)STS	Body	Amplifier (Bose)																																																														
D	2006	(DW)STS	Body	Digital Radio Receiver																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2006	(DW)STS	Body	Distance Sensing Cruise Control																																																														
D	2006	(DW)STS	Body	Driver Door Module																																																														
D	2006	(DW)STS	Body	Driver Door Switch																																																														
D	2006	(DW)STS	Body	Driver Position Module																																																														
D	2006	(DW)STS	Body	Headlamp Control Module																																																														
D	2006	(DW)STS	Body	Head Up Display																																																														
D	2006	(DW)STS	Body	HVAC Control Module																																																														
D	2006	(DW)STS	Body	Instrument Panel Cluster																																																														
D	2006	(DW)STS	Body	Instrument Panel Module																																																														
D	2006	(DW)STS	Body	Left Rear Door Module																																																														
D	2006	(DW)STS	Body	Passenger Door Module																																																														
D	2006	(DW)STS	Body	Uplevel Radio																																																														
D	2006	(DW)STS	Body	Navigation Radio																																																														
D	2006	(DW)STS	Body	Rear Integration Module																																																														
D	2006	(DW)STS	Body	Remote Control Door Lock Receiver																																																														
D	2006	(DW)STS	Body	Right Rear Door Module																																																														
D	2006	(DW)STS	Body	Steering Column Lock Module																																																														
D	2006	(DW)STS	Body	Supplemental Inflatable Restraint																																																														
D	2006	(DW)STS	Body	TV Antenna Module																																																														
D	2006	(DW)STS	Body	Vehicle Comm. Interface Module																																																														
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																														
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																														
D	2006	(DX)STS-V	Chassis	Electronic Brake Control Module																																																														
D	2006	(DX)STS-V	Chassis	Electronic Suspension Control																																																														
D	2006	(DX)STS-V	Body	Amplifier (Bose)																																																														
D	2006	(DX)STS-V	Body	Digital Radio Receiver																																																														
D	2006	(DX)STS-V	Body	Distance Sensing Cruise Control																																																														
D	2006	(DX)STS-V	Body	Driver Door Module																																																														
D	2006	(DX)STS-V	Body	Driver Door Switch																																																														
D	2006	(DX)STS-V	Body	Driver Position Module																																																														
D	2006	(DX)STS-V	Body	Headlamp Control Module																																																														
D	2006	(DX)STS-V	Body	Head Up Display																																																														
D	2006	(DX)STS-V	Body	HVAC Control Module																																																														
D	2006	(DX)STS-V	Body	Instrument Panel Cluster																																																														
D	2006	(DX)STS-V	Body	Instrument Panel Module																																																														
D	2006	(DX)STS-V	Body	Left Rear Door Module																																																														
D	2006	(DX)STS-V	Body	Passenger Door Module																																																														
D	2006	(DX)STS-V	Body	Uplevel Radio																																																														
D	2006	(DX)STS-V	Body	Navigation Radio																																																														
D	2006	(DX)STS-V	Body	Rear Integration Module																																																														
D	2006	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																														
D	2006	(DX)STS-V	Body	Right Rear Door Module																																																														
D	2006	(DX)STS-V	Body	Steering Column Lock Module																																																														
D	2006	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																														
D	2006	(DX)STS-V	Body	TV Antenna Module																																																														
D	2006	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																														
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																														
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																														
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																														
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																														
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2007	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2007	(DM)CTS	Chassis	VES																																																											
D	2007	(DM)CTS	Body	Amplifier (Bose)																																																											
D	2007	(DM)CTS	Body	Amplifier (Delco)																																																											
D	2007	(DM)CTS	Body	Climate Control Panel																																																											
D	2007	(DM)CTS	Body	Dash Integration Module																																																											
D	2007	(DM)CTS	Body	Digital Radio Receiver																																																											
D	2007	(DM)CTS	Body	Driver Door Switch																																																											
D	2007	(DM)CTS	Body	Driver Door Module																																																											
D	2007	(DM)CTS	Body	Passenger Door Module																																																											
D	2007	(DM)CTS	Body	Left Rear Door Module																																																											
D	2007	(DM)CTS	Body	Right Rear Door Module																																																											
D	2007	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2007	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2007	(DM)CTS	Body	Instrument Panel Cluster																																																											
D	2007	(DM)CTS	Body	Memory Seat Module																																																											
D	2007	(DM)CTS	Body	Personalization																																																											
D	2007	(DM)CTS	Body	Rear Integration Module																																																											
D	2007	(DM)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2007	(DM)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2007	(DM)CTS	Body	Theft Deterrent Module																																																											
D	2007	(DM)CTS	Body	TV Antenna Module																																																											
D	2007	(DM)CTS	Body	Vehicle Comm. Interface Module																																																											
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																											
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																											
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																											
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																											
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2007	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2007	(DP)CTS	Chassis	VES																																																											
D	2007	(DP)CTS	Body	Amplifier (Bose)																																																											
D	2007	(DP)CTS	Body	Amplifier (Delco)																																																											
D	2007	(DP)CTS	Body	Climate Control Panel																																																											
D	2007	(DP)CTS	Body	Dash Integration Module																																																											
D	2007	(DP)CTS	Body	Digital Radio Receiver																																																											
D	2007	(DP)CTS	Body	Driver Door Switch																																																											
D	2007	(DP)CTS	Body	Driver Door Module																																																											
D	2007	(DP)CTS	Body	Passenger Door Module																																																											
D	2007	(DP)CTS	Body	Left Rear Door Module																																																											
D	2007	(DP)CTS	Body	Right Rear Door Module																																																											
D	2007	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2007	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2007	(DP)CTS	Body	Instrument Panel Cluster																																																											
D	2007	(DP)CTS	Body	Memory Seat Module																																																											
D	2007	(DP)CTS	Body	Personalization																																																											
D	2007	(DP)CTS	Body	Rear Integration Module																																																											
D	2007	(DP)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2007	(DP)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2007	(DP)CTS	Body	Theft Deterrent Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2007	(DP)CTS	Body	TV Antenna Module																																																												
D	2007	(DP)CTS	Body	Vehicle Comm. Interface Module																																																												
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																												
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																												
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																												
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																												
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2007	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2007	(DR)CTS	Chassis	VES																																																												
D	2007	(DR)CTS	Body	Amplifier (Bose)																																																												
D	2007	(DR)CTS	Body	Amplifier (Delco)																																																												
D	2007	(DR)CTS	Body	Climate Control Panel																																																												
D	2007	(DR)CTS	Body	Dash Integration Module																																																												
D	2007	(DR)CTS	Body	Digital Radio Receiver																																																												
D	2007	(DR)CTS	Body	Driver Door Switch																																																												
D	2007	(DR)CTS	Body	Driver Door Module																																																												
D	2007	(DR)CTS	Body	Passenger Door Module																																																												
D	2007	(DR)CTS	Body	Left Rear Door Module																																																												
D	2007	(DR)CTS	Body	Right Rear Door Module																																																												
D	2007	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2007	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2007	(DR)CTS	Body	Instrument Panel Cluster																																																												
D	2007	(DR)CTS	Body	Memory Seat Module																																																												
D	2007	(DR)CTS	Body	Personalization																																																												
D	2007	(DR)CTS	Body	Rear Integration Module																																																												
D	2007	(DR)CTS	Body	Remote Control Door Lock Receiver																																																												
D	2007	(DR)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2007	(DR)CTS	Body	Theft Deterrent Module																																																												
D	2007	(DR)CTS	Body	TV Antenna Module																																																												
D	2007	(DR)CTS	Body	Vehicle Comm. Interface Module																																																												
D	2007	(DN)CTS-V	Powertrain	(U)6.0L V8 LS2 Engine Control Module																																																												
D	2007	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																												
D	2007	(DN)CTS-V	Chassis	VES																																																												
D	2007	(DN)CTS-V	Body	Amplifier (Bose)																																																												
D	2007	(DN)CTS-V	Body	Amplifier (Delco)																																																												
D	2007	(DN)CTS-V	Body	Climate Control Panel																																																												
D	2007	(DN)CTS-V	Body	Dash Integration Module																																																												
D	2007	(DN)CTS-V	Body	Digital Radio Receiver																																																												
D	2007	(DN)CTS-V	Body	Driver Door Switch																																																												
D	2007	(DN)CTS-V	Body	Driver Door Module																																																												
D	2007	(DN)CTS-V	Body	Passenger Door Module																																																												
D	2007	(DN)CTS-V	Body	Left Rear Door Module																																																												
D	2007	(DN)CTS-V	Body	Right Rear Door Module																																																												
D	2007	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																											
D	2007	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																											
D	2007	(DN)CTS-V	Body	Instrument Panel Cluster																																																											
D	2007	(DN)CTS-V	Body	Memory Seat Module																																																											
D	2007	(DN)CTS-V	Body	Personalization																																																											
D	2007	(DN)CTS-V	Body	Rear Integration Module																																																											
D	2007	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2007	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																														
D	2007	(DN)CTS-V	Body	Theft Deterrent Module																																																														
D	2007	(DN)CTS-V	Body	TV Antenna Module																																																														
D	2007	(DN)CTS-V	Body	Vehicle Comm. Interface Module																																																														
D	2007	(DC)STS-V8	Powertrain	Engine Control Module																																																														
D	2007	(DC)STS-V8	Powertrain	Transmission Control Module																																																														
D	2007	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																														
D	2007	(DC)STS-V8	Chassis	Electronic Suspension Control																																																														
D	2007	(DC)STS-V8	Body	Amplifier (Bose)																																																														
D	2007	(DC)STS-V8	Body	Digital Radio Receiver																																																														
D	2007	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																														
D	2007	(DC)STS-V8	Body	Driver Door Module																																																														
D	2007	(DC)STS-V8	Body	Driver Door Switch																																																														
D	2007	(DC)STS-V8	Body	Driver Position Module																																																														
D	2007	(DC)STS-V8	Body	Headlamp Control Module																																																														
D	2007	(DC)STS-V8	Body	Head Up Display																																																														
D	2007	(DC)STS-V8	Body	HVAC Control Module																																																														
D	2007	(DC)STS-V8	Body	Instrument Panel Cluster																																																														
D	2007	(DC)STS-V8	Body	Instrument Panel Module																																																														
D	2007	(DC)STS-V8	Body	Left Rear Door Module																																																														
D	2007	(DC)STS-V8	Body	Passenger Door Module																																																														
D	2007	(DC)STS-V8	Body	Uplevel Radio																																																														
D	2007	(DC)STS-V8	Body	Navigation Radio																																																														
D	2007	(DC)STS-V8	Body	Rear Integration Module																																																														
D	2007	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																														
D	2007	(DC)STS-V8	Body	Right Rear Door Module																																																														
D	2007	(DC)STS-V8	Body	Steering Column Lock Module																																																														
D	2007	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																														
D	2007	(DC)STS-V8	Body	TV Antenna Module																																																														
D	2007	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																														
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																														
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
D	2007	(DW)STS	Chassis	Electronic Brake Control Module																																																														
D	2007	(DW)STS	Chassis	Electronic Suspension Control																																																														
D	2007	(DW)STS	Body	Amplifier (Bose)																																																														
D	2007	(DW)STS	Body	Digital Radio Receiver																																																														
D	2007	(DW)STS	Body	Distance Sensing Cruise Control																																																														
D	2007	(DW)STS	Body	Driver Door Module																																																														
D	2007	(DW)STS	Body	Driver Door Switch																																																														
D	2007	(DW)STS	Body	Driver Position Module																																																														
D	2007	(DW)STS	Body	Headlamp Control Module																																																														
D	2007	(DW)STS	Body	Head Up Display																																																														
D	2007	(DW)STS	Body	HVAC Control Module																																																														
D	2007	(DW)STS	Body	Instrument Panel Cluster																																																														
D	2007	(DW)STS	Body	Instrument Panel Module																																																														
D	2007	(DW)STS	Body	Left Rear Door Module																																																														
D	2007	(DW)STS	Body	Passenger Door Module																																																														
D	2007	(DW)STS	Body	Uplevel Radio																																																														
D	2007	(DW)STS	Body	Navigation Radio																																																														
D	2007	(DW)STS	Body	Rear Integration Module																																																														
D	2007	(DW)STS	Body	Remote Control Door Lock Receiver																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2007	(DW)STS	Body	Right Rear Door Module																																																												
D	2007	(DW)STS	Body	Steering Column Lock Module																																																												
D	2007	(DW)STS	Body	Supplemental Inflatable Restraint																																																												
D	2007	(DW)STS	Body	TV Antenna Module																																																												
D	2007	(DW)STS	Body	Vehicle Comm. Interface Module																																																												
D	2007	(DX)STS-V	Powertrain	Engine Control Module																																																												
D	2007	(DX)STS-V	Powertrain	Transmission Control Module																																																												
D	2007	(DX)STS-V	Chassis	Electronic Brake Control Module																																																												
D	2007	(DX)STS-V	Chassis	Electronic Suspension Control																																																												
D	2007	(DX)STS-V	Body	Amplifier (Bose)																																																												
D	2007	(DX)STS-V	Body	Digital Radio Receiver																																																												
D	2007	(DX)STS-V	Body	Distance Sensing Cruise Control																																																												
D	2007	(DX)STS-V	Body	Driver Door Module																																																												
D	2007	(DX)STS-V	Body	Driver Door Switch																																																												
D	2007	(DX)STS-V	Body	Driver Position Module																																																												
D	2007	(DX)STS-V	Body	Headlamp Control Module																																																												
D	2007	(DX)STS-V	Body	Head Up Display																																																												
D	2007	(DX)STS-V	Body	HVAC Control Module																																																												
D	2007	(DX)STS-V	Body	Instrument Panel Cluster																																																												
D	2007	(DX)STS-V	Body	Instrument Panel Module																																																												
D	2007	(DX)STS-V	Body	Left Rear Door Module																																																												
D	2007	(DX)STS-V	Body	Passenger Door Module																																																												
D	2007	(DX)STS-V	Body	Uplevel Radio																																																												
D	2007	(DX)STS-V	Body	Navigation Radio																																																												
D	2007	(DX)STS-V	Body	Rear Integration Module																																																												
D	2007	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																												
D	2007	(DX)STS-V	Body	Right Rear Door Module																																																												
D	2007	(DX)STS-V	Body	Steering Column Lock Module																																																												
D	2007	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																												
D	2007	(DX)STS-V	Body	TV Antenna Module																																																												
D	2007	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																												
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																												
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																												
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																												
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																												
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																												
D	2008	CTS	Chassis	Electronic Brake Control Module																																																												
D	2008	CTS	Body	Body Control Module																																																												
D	2008	CTS	Body	Body Control Module (aux.)																																																												
D	2008	CTS	Body	Driver Door Switch																																																												
D	2008	CTS	Body	Headlamp Control Module																																																												
D	2008	CTS	Body	HVAC Control Module																																																												
D	2008	CTS	Body	Infotainment Faceplate Module																																																												
D	2008	CTS	Body	Instrument Panel Cluster																																																												
D	2008	CTS	Body	Memory Seat Module																																																												
D	2008	CTS	Body	Park Assist Module																																																												
D	2008	CTS	Body	Passenger Door Switch																																																												
D	2008	CTS	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2008	CTS	Body	Pedestrian Impact Detection Module																																																											
D	2008	CTS	Body	Radio																																																											
D	2008	CTS	Body	Supplemental Inflatable Restraint																																																											
D	2008	CTS	Body	TV Antenna Module																																																											
D	2008	CTS	Body	Vehicle Comm. Interface Module																																																											
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																											
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
D	2008	SLS	Chassis	Electronic Brake Control Module																																																											
D	2008	SLS	Chassis	Electronic Suspension Control																																																											
D	2008	SLS	Body	Amplifier (Bose)																																																											
D	2008	SLS	Body	Driver Door Module																																																											
D	2008	SLS	Body	Driver Door Switch																																																											
D	2008	SLS	Body	Driver Position Module																																																											
D	2008	SLS	Body	Headlamp Control Module																																																											
D	2008	SLS	Body	HVAC Control Module																																																											
D	2008	SLS	Body	Instrument Panel Cluster																																																											
D	2008	SLS	Body	Instrument Panel Module																																																											
D	2008	SLS	Body	Left Rear Door Module																																																											
D	2008	SLS	Body	Passenger Door Module																																																											
D	2008	SLS	Body	Radio																																																											
D	2008	SLS	Body	Rear HVAC/RSA																																																											
D	2008	SLS	Body	Rear Integration Module																																																											
D	2008	SLS	Body	Remote Control Door Lock Receiver																																																											
D	2008	SLS	Body	Right Rear Door Module																																																											
D	2008	SLS	Body	Supplemental Inflatable Restraint																																																											
D	2008	SLS	Body	TV Antenna Module																																																											
D	2008	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																											
D	2008	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																											
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																											
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																											
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																											
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
D	2008	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																											
D	2008	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																											
D	2008	STS	Chassis	Power Steering Control Module With (RPO JL7)	V																																																										
D	2008	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)		V	V	V	V																																																						
D	2008	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																											
D	2008	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																											
D	2008	STS	Body	Amplifier (Bose)																																																											
D	2008	STS	Body	Digital Radio Receiver																																																											
D	2008	STS	Body	Distance Sensing Cruise Control																																																											
D	2008	STS	Body	Driver Door Module																																																											
D	2008	STS	Body	Driver Door Switch																																																											
D	2008	STS	Body	Driver Position Module																																																											
D	2008	STS	Body	Headlamp Control Module																																																											
D	2008	STS	Body	Head Up Display																																																											
D	2008	STS	Body	HVAC Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | New Actuator Setup Procedure | VSCM Data | Signal Data | VSCM Disable Reason | VSCM Power Steering Reset | Range Measurements | Module Data | Inhibit Data | Calibrate Module | Exh. Aftertreatment Data | Parking Brake Shoe Service Reset | Parking Brake Actuator DTC Reset | Parking Brake Switch Procedure | Charging Info | RVS Disable 1 History | RVS Disable 2 History | RVS Disable 3 History | RVS Disable 4 History | RVS Disable 5 History | RVS Disable 6 History | RVS Disable 7 History | Passenger presence system learn | Signal Type | Module ID Information | Open History Data | Close History Data | Last Open Fail Data | Last Close Fail Data | Obstacle Detect Opening Data | Obstacle Detect Closing Data | LGM Open/Close Test | Deployment Loop 1-14 Resistance | Deployment Loop 15-18 Resistance | Deployment Loop Configuration | Sensor Configuration | Parking Brake Calibration | CAN Bus Communication | Remote Vehicle Start Data | Remote Vehicle Start Disable History 1 Data | Remote Vehicle Start Disable History 2 Data | Remote Vehicle Start Disable History 3 Data | Remote Vehicle Start Disable History 4 Data | Remote Vehicle Start Disable History 5 Data | Remote Vehicle Start Disable History 6 Data | Remote Vehicle Start Disable History 7 Data | Steering Wheel Control Switches | Vehicle Access | Passenger Presence Data | HVAC Door Position Data | A/C Permission Data | Last Liftgate Close Malfunction Data | Last Liftgate Open Malfunction Data | Engineering Data 1 | Engineering Data 2 | Seat Position Data | Steering Column Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																														
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																														
D	2009	SLS	Chassis	Electronic Brake Control Module																																																														
D	2009	SLS	Chassis	Electronic Suspension Control																																																														
D	2009	SLS	Body	Amplifier (Bose)																																																														
D	2009	SLS	Body	Driver Door Module																																																														
D	2009	SLS	Body	Driver Door Switch																																																														
D	2009	SLS	Body	Driver Position Module																																																														
D	2009	SLS	Body	Headlamp Control Module																																																														
D	2009	SLS	Body	HVAC Control Module																																																														
D	2009	SLS	Body	Instrument Panel Cluster																																																														
D	2009	SLS	Body	Instrument Panel Module																																																														
D	2009	SLS	Body	Left Rear Door Module																																																														
D	2009	SLS	Body	Passenger Door Module																																																														
D	2009	SLS	Body	Radio																																																														
D	2009	SLS	Body	Rear HVAC/RSA																																																														
D	2009	SLS	Body	Rear Integration Module																																																														
D	2009	SLS	Body	Remote Control Door Lock Receiver																																																														
D	2009	SLS	Body	Right Rear Door Module																																																														
D	2009	SLS	Body	Supplemental Inflatable Restraint																																																														
D	2009	SLS	Body	TV Antenna Module																																																														
D	2009	SLS	Body	Vehicle Comm. Interface Module																							V	V																																							
D	2009	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																															
D	2009	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																															
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module										V																																																				
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																															
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module										V																																																				
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																															
D	2009	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																															
D	2009	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																															
D	2009	STS	Chassis	Power Steering Control Module With (RPO JL7)	V																																																														
D	2009	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)		V	V	V	V																																																									
D	2009	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																															
D	2009	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																															
D	2009	STS	Body	Amplifier (Bose)																																																														
D	2009	STS	Body	Digital Radio Receiver																																																															
D	2009	STS	Body	Distance Sensing Cruise Control																																																															
D	2009	STS	Body	Driver Door Module																																																														
D	2009	STS	Body	Driver Door Switch																																																														
D	2009	STS	Body	Driver Position Module																																																														
D	2009	STS	Body	Headlamp Control Module																																																														
D	2009	STS	Body	Head Up Display																																																														
D	2009	STS	Body	HVAC Control Module																																																														
D	2009	STS	Body	Instrument Panel Cluster																																																														
D	2009	STS	Body	Instrument Panel Module																																																														
D	2009	STS	Body	Left Rear Door Module																																																														
D	2009	STS	Body	Left Side Object Detection Module						V																																																							
D	2009	STS	Body	Passenger Door Module																																																														
D	2009	STS	Body	Uplevel Radio																																																														
D	2009	STS	Body	Navigation Radio																																																														
D	2009	STS	Body	Rear Integration Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2009	STS	Body	Remote Control Door Lock Receiver																																																															
D	2009	STS	Body	Right Rear Door Module																																																															
D	2009	STS	Body	Right Side Object Detection Module						V																																																								
D	2009	STS	Body	Steering Column Lock Module																																																															
D	2009	STS	Body	Supplemental Inflatable Restraint																																																															
D	2009	STS	Body	TV Antenna Module																																																															
D	2009	STS	Body	Vehicle Comm. Interface Module																																																															
D	2009	STS	Body	Veh Direction Alert Alarm Warn Mod							V	V	V																																																						
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto										V																																																					
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual										V																																																					
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																																
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																																
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Auto										V																																																					
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Manual										V																																																					
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transmission Control Module																																																															
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Fuel Pump Control Module																																																															
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transfer Case Control Module																																																															
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module Auto																																																															
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																															
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Fuel Pump Control Module																																																															
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																															
D	2010	CTS	Chassis	Electronic Brake Control Module																																																															
D	2010	CTS	Chassis	Electronic Suspension Control																																																															
D	2010	CTS	Chassis	Parking Brake Control Module											V	V	V																																																		
D	2010	CTS	Body	Body Control Module														V	V	V	V	V	V	V	V																																											
D	2010	CTS	Body	Body Control Module (aux.)																																																																
D	2010	CTS	Body	Driver Door Switch																																																																
D	2010	CTS	Body	Headlamp Control Module																																																																
D	2010	CTS	Body	HVAC Control Module																																																																
D	2010	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																																
D	2010	CTS	Body	Instrument Panel Cluster (Other)																																																																
D	2010	CTS	Body	Liftgate Module																									V	V	V	V	V	V	V																																
D	2010	CTS	Body	Memory Seat Module																																																																
D	2010	CTS	Body	Park Assist Module																																																																
D	2010	CTS	Body	Passenger Door Switch																																																																
D	2010	CTS	Body	Passenger Presence System																						V																																									
D	2010	CTS	Body	Pedestrian Impact Detection Module																																																																
D	2010	CTS	Body	Radio																																																																
D	2010	CTS	Body	Supplemental Inflatable Restraint																															V	V	V	V																													
D	2010	CTS	Body	TV Antenna Module																																																																
D	2010	CTS	Body	Vehicle Comm. Interface Module																							V	V																																								
D	2010	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																																
D	2010	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																																
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module										V																																																					
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																																
D	2010	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																																
D	2010	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																																
D	2010	STS	Chassis	Power Steering Control Module With (RPO JL7)	V																																																															
D	2010	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)		V	V	V	V																																																										
D	2010	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																																
D	2010	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																																

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2010	STS	Body	Amplifier (Bose)																																																													
D	2010	STS	Body	Digital Radio Receiver																																																													
D	2010	STS	Body	Distance Sensing Cruise Control																																																													
D	2010	STS	Body	Driver Door Module																																																												
D	2010	STS	Body	Driver Door Switch																																																												
D	2010	STS	Body	Driver Position Module																																																												
D	2010	STS	Body	Headlamp Control Module																																																												
D	2010	STS	Body	Head Up Display																																																												
D	2010	STS	Body	HVAC Control Module																																																												
D	2010	STS	Body	Instrument Panel Cluster																																																												
D	2010	STS	Body	Instrument Panel Module																																																												
D	2010	STS	Body	Left Rear Door Module																																																												
D	2010	STS	Body	Left Side Object Detection Module						V																																																						
D	2010	STS	Body	Passenger Door Module																																																												
D	2010	STS	Body	Uplevel Radio																																																												
D	2010	STS	Body	Navigation Radio																																																												
D	2010	STS	Body	Rear Integration Module																																																												
D	2010	STS	Body	Remote Control Door Lock Receiver																																																												
D	2010	STS	Body	Right Rear Door Module																																																												
D	2010	STS	Body	Right Side Object Detection Module						V																																																						
D	2010	STS	Body	Steering Column Lock Module																																																												
D	2010	STS	Body	Supplemental Inflatable Restraint																																																												
D	2010	STS	Body	TV Antenna Module																																																												
D	2010	STS	Body	Vehicle Comm. Interface Module																							V	V																																					
D	2010	STS	Body	Veh Direction Alert Alarm Warn Mod							V	V	V																																																			
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto										V																																																		
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual										V																																																		
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																												
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																												
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Auto										V																																																	
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Manual										V																																																	
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																												
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																												
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transfer Case Control Module																																																												
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																												
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																												
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Fuel Pump Control Module																																																												
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transfer Case Control Module																																																												
D	2011	CTS	Chassis	Electronic Brake Control Module																																																												
D	2011	CTS	Chassis	Electronic Suspension Control																																																												
D	2011	CTS	Chassis	Parking Brake Control Module																																				V																								
D	2011	CTS	Body	Body Control Module (6.2L V8 LSA)														V	V	V	V	V	V	V	V																																						
D	2011	CTS	Body	Body Control Module (Other)														V	V	V	V	V	V	V	V																																						
D	2011	CTS	Body	Body Control Module (aux.)																																																											
D	2011	CTS	Body	Driver Door Switch																																																											
D	2011	CTS	Body	Headlamp Control Module																																																											
D	2011	CTS	Body	HVAC Control Module																																																											
D	2011	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																											
D	2011	CTS	Body	Instrument Panel Cluster (Other)																																																											
D	2011	CTS	Body	Liftgate Module																									V	V	V	V	V	V	V																												
D	2011	CTS	Body	Memory Seat Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2011	CTS	Body	Park Assist Module																																																										
D	2011	CTS	Body	Passenger Door Switch																																																										
D	2011	CTS	Body	Passenger Presence System																						V																																				
D	2011	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2011	CTS	Body	Radio																																																										
D	2011	CTS	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
D	2011	CTS	Body	TV Antenna Module																																																										
D	2011	CTS	Body	Vehicle Comm. Interface Module																								V																																		
D	2011	STS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																										
D	2011	STS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																										
D	2011	STS	Chassis	Electronic Brake Control Module																																																										
D	2011	STS	Chassis	Electronic Suspension Control																																																										
D	2011	STS	Body	Amplifier (Bose)																																																										
D	2011	STS	Body	Digital Radio Receiver																																																										
D	2011	STS	Body	Distance Sensing Cruise Control																																																										
D	2011	STS	Body	Driver Door Module																																																										
D	2011	STS	Body	Driver Door Switch																																																										
D	2011	STS	Body	Driver Position Module																																																										
D	2011	STS	Body	Headlamp Control Module																																																										
D	2011	STS	Body	Head Up Display																																																										
D	2011	STS	Body	HVAC Control Module																																																										
D	2011	STS	Body	Instrument Panel Cluster																																																										
D	2011	STS	Body	Instrument Panel Module																																																										
D	2011	STS	Body	Left Rear Door Module																																																										
D	2011	STS	Body	Left Side Object Detection Module						V																																																				
D	2011	STS	Body	Passenger Door Module																																																										
D	2011	STS	Body	Uplevel Radio																																																										
D	2011	STS	Body	Navigation Radio																																																										
D	2011	STS	Body	Rear Integration Module																																																										
D	2011	STS	Body	Remote Control Door Lock Receiver																																																										
D	2011	STS	Body	Right Rear Door Module																																																										
D	2011	STS	Body	Right Side Object Detection Module						V																																																				
D	2011	STS	Body	Supplemental Inflatable Restraint																																																										
D	2011	STS	Body	TV Antenna Module																																																										
D	2011	STS	Body	Vehicle Comm. Interface Module																							V	V																																		
D	2011	STS	Body	Veh Direction Alert Alarm Warn Mod							V	V	V																																																	
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto										V																																																
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual										V																																																
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2012	P Type Engine	Chassis	Electronic Brake Control Module																																																										
D	2012	P Type Engine	Chassis	Electronic Suspension Control																																																										
D	2012	P Type Engine	Chassis	Parking Brake Control Module																																			V																							
D	2012	P Type Engine	Body	Body Control Module														V	V	V	V	V	V	V	V																																					
D	2012	P Type Engine	Body	Body Control Module (aux.)																																																										
D	2012	P Type Engine	Body	Driver Door Switch																																																										
D	2012	P Type Engine	Body	Headlamp Control Module																																																										
D	2012	P Type Engine	Body	HVAC Control Module																																																										
D	2012	P Type Engine	Body	Instrument Panel Cluster																																																										
D	2012	P Type Engine	Body	Left Side Object Detection Module						V																																																				
D	2012	P Type Engine	Body	Liftgate Module																									V	V	V	V	V	V	V																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2012	P Type Engine	Body	Memory Seat Module																																																													
D	2012	P Type Engine	Body	Park Assist Module																																																													
D	2012	P Type Engine	Body	Passenger Door Switch																																																												
D	2012	P Type Engine	Body	Passenger Presence System																						V																																							
D	2012	P Type Engine	Body	Pedestrian Impact Detection Module																																																												
D	2012	P Type Engine	Body	Radio																																																												
D	2012	P Type Engine	Body	Right Side Object Detection Module						V																																																						
D	2012	P Type Engine	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
D	2012	P Type Engine	Body	TV Antenna Module																																																												
D	2012	P Type Engine	Body	Vehicle Comm. Interface Module																								V																																					
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto										V																																																		
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual										V																																																		
D	2012	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																												
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																												
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																												
D	2012	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module										V																																																		
D	2012	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																												
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																												
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																												
D	2012	Other	Chassis	Electronic Brake Control Module																																																												
D	2012	Other	Chassis	Electronic Suspension Control																																																												
D	2012	Other	Chassis	Parking Brake Control Module																																				V																								
D	2012	Other	Body	Body Control Module														V	V	V	V	V	V	V	V																																							
D	2012	Other	Body	Body Control Module (aux.)																																																												
D	2012	Other	Body	Driver Door Switch																																																												
D	2012	Other	Body	Headlamp Control Module																																																												
D	2012	Other	Body	HVAC Control Module																																																												
D	2012	Other	Body	Instrument Panel Cluster																																																												
D	2012	Other	Body	Left Side Object Detection Module						V																																																						
D	2012	Other	Body	Liftgate Module																									V	V	V	V	V	V	V																													
D	2012	Other	Body	Memory Seat Module																																																												
D	2012	Other	Body	Park Assist Module																																																												
D	2012	Other	Body	Passenger Door Switch																																																												
D	2012	Other	Body	Passenger Presence System																						V																																							
D	2012	Other	Body	Pedestrian Impact Detection Module																																																													
D	2012	Other	Body	Radio																																																												
D	2012	Other	Body	Right Side Object Detection Module						V																																																						
D	2012	Other	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
D	2012	Other	Body	TV Antenna Module																																																												
D	2012	Other	Body	Vehicle Comm. Interface Module																								V																																					
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto										V																																																		
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual										V																																																		
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																												
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																												
D	2013	P Type Engine	Chassis	Electronic Brake Control Module																																																												
D	2013	P Type Engine	Chassis	Electronic Suspension Control																																																												
D	2013	P Type Engine	Chassis	Parking Brake Control Module																																				V																								
D	2013	P Type Engine	Body	Body Control Module														V	V	V	V	V	V	V	V																																							
D	2013	P Type Engine	Body	Body Control Module (aux.)																																																												
D	2013	P Type Engine	Body	Driver Door Switch																																																												
D	2013	P Type Engine	Body	Headlamp Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2013	P Type Engine	Body	HVAC Control Module																																																											
D	2013	P Type Engine	Body	Instrument Panel Cluster																																																											
D	2013	P Type Engine	Body	Left Side Object Detection Module						V																																																				
D	2013	P Type Engine	Body	Liftgate Module																								V	V	V	V	V	V	V																												
D	2013	P Type Engine	Body	Memory Seat Module																																																										
D	2013	P Type Engine	Body	Park Assist Module																																																										
D	2013	P Type Engine	Body	Passenger Door Switch																																																										
D	2013	P Type Engine	Body	Passenger Presence System																						V																																				
D	2013	P Type Engine	Body	Pedestrian Impact Detection Module																																																										
D	2013	P Type Engine	Body	Radio																																																										
D	2013	P Type Engine	Body	Right Side Object Detection Module						V																																																				
D	2013	P Type Engine	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
D	2013	P Type Engine	Body	TV Antenna Module																																																										
D	2013	P Type Engine	Body	Vehicle Comm. Interface Module																								V																																			
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto										V																																																
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual										V																																																
D	2013	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																										
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																										
D	2013	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module										V																																																
D	2013	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																										
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																										
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																										
D	2013	Other	Chassis	Electronic Brake Control Module																																																										
D	2013	Other	Chassis	Electronic Suspension Control																																																										
D	2013	Other	Chassis	Parking Brake Control Module																																				V																						
D	2013	Other	Body	Body Control Module														V	V	V	V	V	V	V	V																																					
D	2013	Other	Body	Body Control Module (aux.)																																																										
D	2013	Other	Body	Driver Door Switch																																																										
D	2013	Other	Body	Headlamp Control Module																																																										
D	2013	Other	Body	HVAC Control Module																																																										
D	2013	Other	Body	Instrument Panel Cluster																																																										
D	2013	Other	Body	Left Side Object Detection Module						V																																																				
D	2013	Other	Body	Liftgate Module																								V	V	V	V	V	V	V																												
D	2013	Other	Body	Memory Seat Module																																																										
D	2013	Other	Body	Park Assist Module																																																										
D	2013	Other	Body	Passenger Door Switch																																																										
D	2013	Other	Body	Passenger Presence System																						V																																				
D	2013	Other	Body	Pedestrian Impact Detection Module																																																											
D	2013	Other	Body	Radio																																																										
D	2013	Other	Body	Right Side Object Detection Module						V																																																				
D	2013	Other	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
D	2013	Other	Body	TV Antenna Module																																																										
D	2013	Other	Body	Vehicle Comm. Interface Module																								V																																			
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
D	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
D	2014	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																										
D	2014	CTS	Powertrain	Chassis Control Module																																																										

| Engine type | Year | Model | System 1 | System 2 | New Actuator Setup Procedure | VSCM Data | Signal Data | VSCM Disable Reason | VSCM Power Steering Reset | Range Measurements | Module Data | Inhibit Data | Calibrate Module | Exh. Aftertreatment Data | Parking Brake Shoe Service Reset | Parking Brake Actuator DTC Reset | Parking Brake Switch Procedure | Charging Info | RVS Disable 1 History | RVS Disable 2 History | RVS Disable 3 History | RVS Disable 4 History | RVS Disable 5 History | RVS Disable 6 History | RVS Disable 7 History | Passenger presence system learn | Signal Type | Module ID Information | Open History Data | Close History Data | Last Open Fail Data | Last Close Fail Data | Obstacle Detect Opening Data | Obstacle Detect Closing Data | LGM Open/Close Test | Deployment Loop 1-14 Resistance | Deployment Loop 15-18 Resistance | Deployment Loop Configuration | Sensor Configuration | Parking Brake Calibration | CAN Bus Communication | Remote Vehicle Start Data | Remote Vehicle Start Disable History 1 Data | Remote Vehicle Start Disable History 2 Data | Remote Vehicle Start Disable History 3 Data | Remote Vehicle Start Disable History 4 Data | Remote Vehicle Start Disable History 5 Data | Remote Vehicle Start Disable History 6 Data | Remote Vehicle Start Disable History 7 Data | Steering Wheel Control Switches | Vehicle Access | Passenger Presence Data | HVAC Door Position Data | A/C Permission Data | Last Liftgate Close Malfunction Data | Last Liftgate Open Malfunction Data | Engineering Data 1 | Engineering Data 2 | Seat Position Data | Steering Column Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | New Actuator Setup Procedure | VSCM Data | Signal Data | VSCM Disable Reason | VSCM Power Steering Reset | Range Measurements | Module Data | Inhibit Data | Calibrate Module | Exh. Aftertreatment Data | Parking Brake Shoe Service Reset | Parking Brake Actuator DTC Reset | Parking Brake Switch Procedure | Charging Info | RVS Disable 1 History | RVS Disable 2 History | RVS Disable 3 History | RVS Disable 4 History | RVS Disable 5 History | RVS Disable 6 History | RVS Disable 7 History | Passenger presence system learn | Signal Type | Module ID Information | Open History Data | Close History Data | Last Open Fail Data | Last Close Fail Data | Obstacle Detect Opening Data | Obstacle Detect Closing Data | LGM Open/Close Test | Deployment Loop 1-14 Resistance | Deployment Loop 15-18 Resistance | Deployment Loop Configuration | Sensor Configuration | Parking Brake Calibration | CAN Bus Communication | Remote Vehicle Start Data | Remote Vehicle Start Disable History 1 Data | Remote Vehicle Start Disable History 2 Data | Remote Vehicle Start Disable History 3 Data | Remote Vehicle Start Disable History 4 Data | Remote Vehicle Start Disable History 5 Data | Remote Vehicle Start Disable History 6 Data | Remote Vehicle Start Disable History 7 Data | Steering Wheel Control Switches | Vehicle Access | Passenger Presence Data | HVAC Door Position Data | A/C Permission Data | Last Liftgate Close Malfunction Data | Last Liftgate Open Malfunction Data | Engineering Data 1 | Engineering Data 2 | Seat Position Data | Steering Column Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2004	(KE)DHS	Body	Remote Function Actuation																																																												
K	2004	(KE)DHS	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KE)DHS	Body	Tilt Telescope Module																																																												
K	2004	(KE)DHS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																												
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																												
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																												
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																												
K	2004	(KF)DTS	Body	Amplifier (Bose)																																																												
K	2004	(KF)DTS	Body	CD Changer																																																												
K	2004	(KF)DTS	Body	Dash Integration Module																																																												
K	2004	(KF)DTS	Body	Digital Radio Receiver																																																												
K	2004	(KF)DTS	Body	Driver Door Switch																																																												
K	2004	(KF)DTS	Body	Driver Door Module																																																												
K	2004	(KF)DTS	Body	Passenger Door Module																																																												
K	2004	(KF)DTS	Body	Left Rear Door Module																																																												
K	2004	(KF)DTS	Body	Right Rear Door Module																																																												
K	2004	(KF)DTS	Body	Instrument Panel Cluster																																																												
K	2004	(KF)DTS	Body	Instrument Panel Module																																																												
K	2004	(KF)DTS	Body	Memory Seat Module																																																												
K	2004	(KF)DTS	Body	Navigation Radio																																																												
K	2004	(KF)DTS	Body	Radio																																																												
K	2004	(KF)DTS	Body	Rear Climate Control Panel																																																												
K	2004	(KF)DTS	Body	Rear Integration Module																																																												
K	2004	(KF)DTS	Body	Remote Function Actuation																																																												
K	2004	(KF)DTS	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KF)DTS	Body	Tilt Telescope Module																																																												
K	2004	(KF)DTS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																												
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																												
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																												
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																												
K	2004	(KS)Seville SLS	Body	Amplifier (Bose)																																																												
K	2004	(KS)Seville SLS	Body	Amplifier (Delco)																																																												
K	2004	(KS)Seville SLS	Body	CD Changer																																																												
K	2004	(KS)Seville SLS	Body	Dash Integration Module																																																												
K	2004	(KS)Seville SLS	Body	Digital Radio Receiver																																																												
K	2004	(KS)Seville SLS	Body	Driver Door Module																																																												
K	2004	(KS)Seville SLS	Body	Instrument Panel Cluster																																																												
K	2004	(KS)Seville SLS	Body	Instrument Panel Module																																																												
K	2004	(KS)Seville SLS	Body	Memory Seat Module																																																												
K	2004	(KS)Seville SLS	Body	Navigation Radio																																																												
K	2004	(KS)Seville SLS	Body	Radio																																																												
K	2004	(KS)Seville SLS	Body	Rear Integration Module																																																												
K	2004	(KS)Seville SLS	Body	Remote Function Actuation																																																												
K	2004	(KS)Seville SLS	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KS)Seville SLS	Body	Tilt Telescope Module																																																												
K	2004	(KS)Seville SLS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																												
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																												
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																											
K	2004	(KY)Seville STS	Body	Amplifier (Bose)																																																											
K	2004	(KY)Seville STS	Body	Amplifier (Delco)																																																											
K	2004	(KY)Seville STS	Body	CD Changer																																																											
K	2004	(KY)Seville STS	Body	Dash Integration Module																																																											
K	2004	(KY)Seville STS	Body	Digital Radio Receiver																																																											
K	2004	(KY)Seville STS	Body	Driver Door Module																																																											
K	2004	(KY)Seville STS	Body	Instrument Panel Cluster																																																											
K	2004	(KY)Seville STS	Body	Instrument Panel Module																																																											
K	2004	(KY)Seville STS	Body	Memory Seat Module																																																											
K	2004	(KY)Seville STS	Body	Navigation Radio																																																											
K	2004	(KY)Seville STS	Body	Radio																																																											
K	2004	(KY)Seville STS	Body	Rear Integration Module																																																											
K	2004	(KY)Seville STS	Body	Remote Function Actuation																																																											
K	2004	(KY)Seville STS	Body	Supplemental Inflatable Restraint																																																											
K	2004	(KY)Seville STS	Body	Tilt Telescope Module																																																											
K	2004	(KY)Seville STS	Body	Vehicle Theft Deterrent																																																											
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																											
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																											
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																											
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																											
K	2005	(KD)Deville	Body	Amplifier (Delco)																																																											
K	2005	(KD)Deville	Body	CD Changer																																																											
K	2005	(KD)Deville	Body	Dash Integration Module																																																											
K	2005	(KD)Deville	Body	Digital Radio Receiver																																																											
K	2005	(KD)Deville	Body	Driver Door Switch																																																											
K	2005	(KD)Deville	Body	Driver Door Module																																																											
K	2005	(KD)Deville	Body	Passenger Door Module																																																											
K	2005	(KD)Deville	Body	Left Rear Door Module																																																											
K	2005	(KD)Deville	Body	Right Rear Door Module																																																											
K	2005	(KD)Deville	Body	Instrument Panel Cluster																																																											
K	2005	(KD)Deville	Body	Instrument Panel Module																																																											
K	2005	(KD)Deville	Body	Memory Seat Module																																																											
K	2005	(KD)Deville	Body	Navigation Radio																																																											
K	2005	(KD)Deville	Body	Radio																																																											
K	2005	(KD)Deville	Body	Rear Climate Control Panel																																																											
K	2005	(KD)Deville	Body	Rear Integration Module																																																											
K	2005	(KD)Deville	Body	Remote Function Actuation																																																											
K	2005	(KD)Deville	Body	Supplemental Inflatable Restraint																																																											
K	2005	(KD)Deville	Body	Tilt Telescope Module																																																											
K	2005	(KD)Deville	Body	Vehicle Theft Deterrent																																																											
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																											
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																											
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																											
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																											
K	2005	(KE)DHS	Body	Amplifier (Bose)																																																											
K	2005	(KE)DHS	Body	CD Changer																																																											
K	2005	(KE)DHS	Body	Dash Integration Module																																																											
K	2005	(KE)DHS	Body	Digital Radio Receiver																																																											
K	2005	(KE)DHS	Body	Driver Door Switch																																																											
K	2005	(KE)DHS	Body	Driver Door Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2005	(KE)DHS	Body	Passenger Door Module																																																															
K	2005	(KE)DHS	Body	Left Rear Door Module																																																															
K	2005	(KE)DHS	Body	Right Rear Door Module																																																															
K	2005	(KE)DHS	Body	Instrument Panel Cluster																																																															
K	2005	(KE)DHS	Body	Instrument Panel Module																																																															
K	2005	(KE)DHS	Body	Memory Seat Module																																																															
K	2005	(KE)DHS	Body	Navigation Radio																																																															
K	2005	(KE)DHS	Body	Radio																																																															
K	2005	(KE)DHS	Body	Rear Climate Control Panel																																																															
K	2005	(KE)DHS	Body	Rear Integration Module																																																															
K	2005	(KE)DHS	Body	Remote Function Actuation																																																															
K	2005	(KE)DHS	Body	Supplemental Inflatable Restraint																																																															
K	2005	(KE)DHS	Body	Tilt Telescope Module																																																															
K	2005	(KE)DHS	Body	Vehicle Theft Deterrent																																																															
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																															
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																															
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																															
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																															
K	2005	(KF)DTS	Body	Amplifier (Bose)																																																															
K	2005	(KF)DTS	Body	CD Changer																																																															
K	2005	(KF)DTS	Body	Dash Integration Module																																																															
K	2005	(KF)DTS	Body	Digital Radio Receiver																																																															
K	2005	(KF)DTS	Body	Driver Door Switch																																																															
K	2005	(KF)DTS	Body	Driver Door Module																																																															
K	2005	(KF)DTS	Body	Passenger Door Module																																																															
K	2005	(KF)DTS	Body	Left Rear Door Module																																																															
K	2005	(KF)DTS	Body	Right Rear Door Module																																																															
K	2005	(KF)DTS	Body	Instrument Panel Cluster																																																															
K	2005	(KF)DTS	Body	Instrument Panel Module																																																															
K	2005	(KF)DTS	Body	Memory Seat Module																																																															
K	2005	(KF)DTS	Body	Navigation Radio																																																															
K	2005	(KF)DTS	Body	Radio																																																															
K	2005	(KF)DTS	Body	Rear Climate Control Panel																																																															
K	2005	(KF)DTS	Body	Rear Integration Module																																																															
K	2005	(KF)DTS	Body	Remote Function Actuation																																																															
K	2005	(KF)DTS	Body	Supplemental Inflatable Restraint																																																															
K	2005	(KF)DTS	Body	Tilt Telescope Module																																																															
K	2005	(KF)DTS	Body	Vehicle Theft Deterrent																																																															
K	2006	ALL	Powertrain	Engine Control Module																																																															
K	2006	ALL	Powertrain	Automatic Transaxle																																																															
K	2006	ALL	Chassis	Antilock Brake System																																																															
K	2006	ALL	Body	Amplifier (Bose)																																																															
K	2006	ALL	Body	Aux. HVAC Control Module																																																															
K	2006	ALL	Body	Body Control Module																																																															
K	2006	ALL	Body	Digital Radio Receiver																																																															
K	2006	ALL	Body	Distance Sensing Cruise Control																																																															
K	2006	ALL	Body	Driver Door Switch																																																															
K	2006	ALL	Body	Driver Position Module																																																															
K	2006	ALL	Body	HVAC Control Module																																																															
K	2006	ALL	Body	Instrument Panel Cluster																																																															
K	2006	ALL	Body	Park Assist Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2006	ALL	Body	Passenger Door Switch																																																													
K	2006	ALL	Body	Passenger Presence System																																																													
K	2006	ALL	Body	Radio																																																												
K	2006	ALL	Body	Rear Heated Seat Module																																																												
K	2006	ALL	Body	Remote Control Door Lock Receiver																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2006	ALL	Body	Theft Deterrent Module																																																												
K	2006	ALL	Body	TV Antenna Module																																																												
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2007	ALL	Powertrain	Engine Control Module																																																												
K	2007	ALL	Powertrain	Transmission Control Module																																																												
K	2007	ALL	Chassis	Electronic Brake Control Module																																																												
K	2007	ALL	Body	Amplifier (Bose)																																																												
K	2007	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																												
K	2007	ALL	Body	Body Control Module																																																												
K	2007	ALL	Body	Digital Radio Receiver																																																												
K	2007	ALL	Body	Distance Sensing Cruise Control																																																												
K	2007	ALL	Body	Driver Door Switch																																																												
K	2007	ALL	Body	Driver Position Module																																																												
K	2007	ALL	Body	CJ2 Dual Zone HVAC Auto																																																												
K	2007	ALL	Body	CJ4 Tri Zone HVAC Auto																																																												
K	2007	ALL	Body	Inside Rear View Mirror Module																																																												
K	2007	ALL	Body	Instrument Panel Cluster																																																												
K	2007	ALL	Body	Park Assist Module																																																												
K	2007	ALL	Body	Passenger Door Switch																																																												
K	2007	ALL	Body	Passenger Presence System																																																												
K	2007	ALL	Body	Radio																																																												
K	2007	ALL	Body	Rear Heated Seat Module																																																												
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2007	ALL	Body	Theft Deterrent Module																																																												
K	2007	ALL	Body	TV Antenna Module																																																												
K	2007	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2008	ALL	Powertrain	Engine Control Module																																																												
K	2008	ALL	Powertrain	Transmission Control Module																																																												
K	2008	ALL	Chassis	Electronic Brake Control Module																																																												
K	2008	ALL	Body	Amplifier (Bose)																																																												
K	2008	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																												
K	2008	ALL	Body	Body Control Module																																																												
K	2008	ALL	Body	Digital Radio Receiver																																																												
K	2008	ALL	Body	Distance Sensing Cruise Control																																																												
K	2008	ALL	Body	Driver Door Switch																																																												
K	2008	ALL	Body	Driver Position Module																																																												
K	2008	ALL	Body	CJ2 Dual Zone HVAC Auto																																																												
K	2008	ALL	Body	CJ4 Tri Zone HVAC Auto																																																												
K	2008	ALL	Body	Inside Rear View Mirror Module																																																												
K	2008	ALL	Body	Instrument Panel Cluster																																																												
K	2008	ALL	Body	Left Side Object Detection Module						V																																																					
K	2008	ALL	Body	Park Assist Module																																																												
K	2008	ALL	Body	Passenger Door Switch																																																												
K	2008	ALL	Body	Passenger Presence System																																																												
K	2008	ALL	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2008	ALL	Body	Rear Heated Seat Module																																																															
K	2008	ALL	Body	Right Side Object Detection Module						V																																																								
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2008	ALL	Body	Theft Deterrent Module																																																														
K	2008	ALL	Body	TV Antenna Module																																																														
K	2008	ALL	Body	Vehicle Comm. Interface Module																																																														
K	2008	ALL	Body	Veh Direction Alert Alarm Warn Mod							V	V	V																																																				
K	2009	ALL	Powertrain	Engine Control Module										V																																																				
K	2009	ALL	Powertrain	Transmission Control Module																																																															
K	2009	ALL	Chassis	Electronic Brake Control Module																																																															
K	2009	ALL	Body	Amplifier (Bose)																																																														
K	2009	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																														
K	2009	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																								
K	2009	ALL	Body	Digital Radio Receiver																																																															
K	2009	ALL	Body	Distance Sensing Cruise Control																																																															
K	2009	ALL	Body	Driver Door Switch																																																															
K	2009	ALL	Body	Driver Position Module																																																															
K	2009	ALL	Body	CJ2 Dual Zone HVAC Auto																																																															
K	2009	ALL	Body	CJ4 Tri Zone HVAC Auto																																																															
K	2009	ALL	Body	Inside Rear View Mirror Module																																																															
K	2009	ALL	Body	Instrument Panel Cluster																																																															
K	2009	ALL	Body	Left Side Object Detection Module						V																																																								
K	2009	ALL	Body	Park Assist Module																																																															
K	2009	ALL	Body	Passenger Door Switch																																																															
K	2009	ALL	Body	Passenger Presence System																																																															
K	2009	ALL	Body	Radio																																																															
K	2009	ALL	Body	Rear Heated Seat Module																																																															
K	2009	ALL	Body	Right Side Object Detection Module						V																																																								
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
K	2009	ALL	Body	Theft Deterrent Module																																																															
K	2009	ALL	Body	TV Antenna Module																																																															
K	2009	ALL	Body	Vehicle Comm. Interface Module																								V																																							
K	2009	ALL	Body	Vehicle Comm. Interface Module																								V																																							
K	2009	ALL	Body	Veh Direction Alert Alarm Warn Mod							V	V	V																																																					
K	2010	ALL	Powertrain	Engine Control Module										V																																																				
K	2010	ALL	Powertrain	Transmission Control Module																																																															
K	2010	ALL	Chassis	Electronic Brake Control Module																																																															
K	2010	ALL	Body	Amplifier (Bose)																																																															
K	2010	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																															
K	2010	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																								
K	2010	ALL	Body	Digital Radio Receiver																																																															
K	2010	ALL	Body	Distance Sensing Cruise Control																																																															
K	2010	ALL	Body	Driver Door Switch																																																															
K	2010	ALL	Body	Driver Position Module																																																															
K	2010	ALL	Body	CJ2 Dual Zone HVAC Auto																																																															
K	2010	ALL	Body	CJ4 Tri Zone HVAC Auto																																																															
K	2010	ALL	Body	Inside Rear View Mirror Module																																																															
K	2010	ALL	Body	Instrument Panel Cluster																																																															
K	2010	ALL	Body	Left Side Object Detection Module						V																																																								
K	2010	ALL	Body	Park Assist Module																																																															
K	2010	ALL	Body	Passenger Door Switch																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2010	ALL	Body	Passenger Presence System																																																												
K	2010	ALL	Body	Radio																																																												
K	2010	ALL	Body	Rear Heated Seat Module																																																												
K	2010	ALL	Body	Right Side Object Detection Module						V																																																						
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2010	ALL	Body	Theft Deterrent Module																																																												
K	2010	ALL	Body	TV Antenna Module																																																												
K	2010	ALL	Body	Vehicle Comm. Interface Module																								V																																				
K	2010	ALL	Body	Veh Direction Alert Alarm Warn Mod							V	V	V																																																			
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Engine Control Module										V																																																		
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Transmission Control Module																																																												
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Engine Control Module										V																																																		
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Transmission Control Module																																																												
K	2011	ALL	Chassis	Electronic Brake Control Module																																																												
K	2011	ALL	Body	Amplifier (Bose)																																																												
K	2011	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																												
K	2011	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2011	ALL	Body	Digital Radio Receiver																																																												
K	2011	ALL	Body	Distance Sensing Cruise Control																																																												
K	2011	ALL	Body	Driver Door Switch																																																												
K	2011	ALL	Body	Driver Position Module																																																												
K	2011	ALL	Body	CJ2 Dual Zone HVAC Auto																																																												
K	2011	ALL	Body	CJ4 Tri Zone HVAC Auto																																																												
K	2011	ALL	Body	Inside Rear View Mirror Module																																																												
K	2011	ALL	Body	Instrument Panel Cluster																																																												
K	2011	ALL	Body	Left Side Object Detection Module						V																																																						
K	2011	ALL	Body	Park Assist Module																																																												
K	2011	ALL	Body	Passenger Door Switch																																																												
K	2011	ALL	Body	Passenger Presence System																																																												
K	2011	ALL	Body	Radio																																																												
K	2011	ALL	Body	Rear Heated Seat Module																																																												
K	2011	ALL	Body	Right Side Object Detection Module						V																																																						
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2011	ALL	Body	Theft Deterrent Module																																																												
K	2011	ALL	Body	TV Antenna Module																																																												
K	2011	ALL	Body	Vehicle Comm. Interface Module																								V																																				
K	2011	ALL	Body	Veh Direction Alert Alarm Warn Mod							V	V	V																																																			
K	2016	CT6	Powertrain	(X) 2.0L LTG Engine Control Module																																																												
K	2016	CT6	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
K	2016	CT6	Powertrain	(6) 3.0L LGW Engine Control Module																																																												
K	2016	CT6	Powertrain	(6) 3.0L LGW Transmission Control Module																																																												
K	2016	CT6	Powertrain	(S) 3.6L LGX Engine Control Module																																																												
K	2016	CT6	Powertrain	(S) 3.6L LGX Transmission Control Module																																																												
K	2016	CT6	Powertrain	Transfer Case Control Module																																																												
K	2016	CT6	Chassis	Electronic Brake Control Module																																																												
K	2016	CT6	Chassis	Brake Booster Control Module																																																												
K	2016	CT6	Chassis	Power Steering Control Module																																																												
K	2016	CT6	Chassis	Rear Wheel Steering Control Module																																																												
K	2016	CT6	Chassis	Suspension Control Module																																																												
K	2016	CT6	Body	Body Control Module																																																												
K	2016	CT6	Body	Serial Data Gateway Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2016	CT6	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
K	2016	CT6	Body	Passenger Presence Module																																																														
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Left																																																													
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Right																																																													
K	2016	CT6	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
K	2016	CT6	Body	Instrument Cluster Full Screen Display (UDV)																																																												
K	2016	CT6	Body	Radio Controls																																																												
K	2016	CT6	Body	HVAC Controls																																																												
K	2016	CT6	Body	Active Safety Control Module																																																												
K	2016	CT6	Body	Video Processing Control Module																																																												
K	2016	CT6	Body	Headlamp Control Module																																																												
K	2016	CT6	Body	Trailer Interface Control Module																																																												
K	2016	CT6	Body	Radio																																																												
K	2016	CT6	Body	Amplifier																																																												
K	2016	CT6	Body	Infotainment Control Touchpad																																																												
K	2016	CT6	Body	Human Machine Interface Control Module																																																												
K	2016	CT6	Body	Navigation Control Module																																																												
K	2016	CT6	Body	Telematics Communication Interface Control Module																																																												
K	2016	CT6	Body	HVAC Control Module																																																												
K	2016	CT6	Body	Liftgate Control Module																																																					V	V	V	V		
K	2016	CT6	Body	Seat Memory Control Module - Passenger																																																												
K	2016	CT6	Body	Seat Memory Control Module - Left Rear																																																												
K	2016	CT6	Body	Seat Memory Control Module - Driver																																																												
K	2016	CT6	Body	Seat Memory Control Module - Right Rear																																																												
K	2016	CT6	Body	Keyless Entry Control Module																																																												
K	2016	CT6	Body	Left Side Object Detection Control Module																																																												
K	2016	CT6	Body	Parking Assist Control Module																																																												
K	2016	CT6	Body	Frontview Camera Module																																																												
K	2016	CT6	Body	Long Range Radar Sensor Module																																																												
K	2016	CT6	Body	Left Front Short Range Radar Sensor Module																																																												
K	2016	CT6	Body	Right Front Short Range Radar Sensor Module																																																												
K	2016	CT6	Body	Rear Short Range Radar Sensor Module																																																												
K	2016	CT6	Body	Night Vision Camera Control Module																																																												
R	2014	ELR	Powertrain	Engine Control Module																																																												
R	2014	ELR	Powertrain	Trasmission Control Module																																																												
R	2014	ELR	Powertrain	Chassis Control Module																																																												
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module																																																												
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																												
R	2014	ELR	Powertrain	Drive Motor Control Module 1																																																												
R	2014	ELR	Powertrain	Drive Motor Control Module 2																																																												
R	2014	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2014	ELR	Chassis	Electronic Brake Control Module																																																												
R	2014	ELR	Chassis	Distance Sensing Cruise Control Module																																																												
R	2014	ELR	Chassis	Parking Brake Control Module																																																												
R	2014	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																												
R	2014	ELR	Chassis	Power Steering Control Module																																																												
R	2014	ELR	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2014	ELR	Chassis	Suspension Control Module																																																												
R	2014	ELR	Body	Body Control Module																																																												
R	2014	ELR	Body	Pedestrian Impact Detection Module																																																												
R	2014	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2014	ELR	Body	Passenger Presence Module																																																													
R	2014	ELR	Body	Instrument Cluster																																																													
R	2014	ELR	Body	Radio/HVAC Control																																																													
R	2014	ELR	Body	Radio																																																												
R	2014	ELR	Body	Amplifier																																																												
R	2014	ELR	Body	Human Machine Interface Control Module																																																												
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	ELR	Body	HVAC Control Module																																																					V							
R	2014	ELR	Body	Electric A/C Compressor Control Module																																																												
R	2014	ELR	Body	Coolant Heater Control Module																																																												
R	2014	ELR	Body	Seat Memory Control Module - Driver																																																												
R	2014	ELR	Body	Keyless Entry Control Module																																																												
R	2014	ELR	Body	Right Side Object Detection Control Module																																																												
R	2014	ELR	Body	Left Side Object Detection Control Module																																																												
R	2014	ELR	Body	Parking Assist Control Module																																																												
R	2014	ELR	Body	Frontview Camera Module																																																												
R	2014	ELR	Body	Steering Column Lock Control Module																																																												
R	2014	ELR	Body	Battery Charger Control Module																																																												
R	2014	ELR	Body	Battery Energy Control Module																																																												
R	2015	ELR	Powertrain	Engine Control Module																																																												
R	2015	ELR	Powertrain	Trasmission Control Module																																																												
R	2015	ELR	Powertrain	Chassis Control Module																																																												
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module																																																												
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																												
R	2015	ELR	Powertrain	Drive Motor Control Module 1																																																												
R	2015	ELR	Powertrain	Drive Motor Control Module 2																																																												
R	2015	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2015	ELR	Chassis	Electronic Brake Control Module																																																												
R	2015	ELR	Chassis	Distance Sensing Cruise Control Module																																																												
R	2015	ELR	Chassis	Parking Brake Control Module																																																												
R	2015	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																												
R	2015	ELR	Chassis	Power Steering Control Module																																																												
R	2015	ELR	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2015	ELR	Chassis	Suspension Control Module																																																												
R	2015	ELR	Body	Body Control Module																																																												
R	2015	ELR	Body	Pedestrian Impact Detection Module																																																												
R	2015	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	ELR	Body	Passenger Presence Module																																																												
R	2015	ELR	Body	Instrument Cluster																																																												
R	2015	ELR	Body	Radio/HVAC Control																																																												
R	2015	ELR	Body	Headlamp Control Module																																																												
R	2015	ELR	Body	Radio																																																												
R	2015	ELR	Body	Amplifier																																																												
R	2015	ELR	Body	Human Machine Interface Control Module																																																												
R	2015	ELR	Body	Telematics Communication Interface Control Module																																																												
R	2015	ELR	Body	HVAC Control Module																																																					V							
R	2015	ELR	Body	Electric A/C Compressor Control Module																																																												
R	2015	ELR	Body	Coolant Heater Control Module																																																												
R	2015	ELR	Body	Seat Memory Control Module - Driver																																																												
R	2015	ELR	Body	Keyless Entry Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | New Actuator Setup Procedure | VSCM Data | Signal Data | VSCM Disable Reason | VSCM Power Steering Reset | Range Measurements | Module Data | Inhibit Data | Calibrate Module | Exh. Aftertreatment Data | Parking Brake Shoe Service Reset | Parking Brake Actuator DTC Reset | Parking Brake Switch Procedure | Charging Info | RVS Disable 1 History | RVS Disable 2 History | RVS Disable 3 History | RVS Disable 4 History | RVS Disable 5 History | RVS Disable 6 History | RVS Disable 7 History | Passenger presence system learn | Signal Type | Module ID Information | Open History Data | Close History Data | Last Open Fail Data | Last Close Fail Data | Obstacle Detect Opening Data | Obstacle Detect Closing Data | LGM Open/Close Test | Deployment Loop 1-14 Resistance | Deployment Loop 15-18 Resistance | Deployment Loop Configuration | Sensor Configuration | Parking Brake Calibration | CAN Bus Communication | Remote Vehicle Start Data | Remote Vehicle Start Disable History 1 Data | Remote Vehicle Start Disable History 2 Data | Remote Vehicle Start Disable History 3 Data | Remote Vehicle Start Disable History 4 Data | Remote Vehicle Start Disable History 5 Data | Remote Vehicle Start Disable History 6 Data | Remote Vehicle Start Disable History 7 Data | Steering Wheel Control Switches | Vehicle Access | Passenger Presence Data | HVAC Door Position Data | A/C Permission Data | Last Liftgate Close Malfunction Data | Last Liftgate Open Malfunction Data | Engineering Data 1 | Engineering Data 2 | Seat Position Data | Steering Column Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Y	2004	ALL	Body	Digital Radio Receiver																																																												
Y	2004	ALL	Body	Distance Sensing Cruise Control																																																												
Y	2004	ALL	Body	Driver Door Module																																																												
Y	2004	ALL	Body	Driver Door Switch																																																												
Y	2004	ALL	Body	Driver Position Module																																																												
Y	2004	ALL	Body	Folding Top Module																																																												
Y	2004	ALL	Body	Head Up Display																																																												
Y	2004	ALL	Body	HVAC Control Module																																																												
Y	2004	ALL	Body	Instrument Panel Cluster																																																												
Y	2004	ALL	Body	Navigation Radio																																																												
Y	2004	ALL	Body	Passenger Door Module																																																												
Y	2004	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2004	ALL	Body	Steering Column Lock Module																																																												
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2005	ALL	Powertrain	Engine Control Module																																																												
Y	2005	ALL	Powertrain	Automatic Transmission																																																												
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2005	ALL	Chassis	Electronic Suspension Control																																																												
Y	2005	ALL	Chassis	Steering Wheel and Column																																																												
Y	2005	ALL	Body	Amplifier (Bose)																																																												
Y	2005	ALL	Body	Body Control Module																																																												V
Y	2005	ALL	Body	CD Changer																																																												
Y	2005	ALL	Body	Digital Radio Receiver																																																												
Y	2005	ALL	Body	Distance Sensing Cruise Control																																																												
Y	2005	ALL	Body	Driver Door Module																																																												
Y	2005	ALL	Body	Driver Door Switch																																																												
Y	2005	ALL	Body	Driver Position Module																																																												
Y	2005	ALL	Body	Folding Top Module																																																												
Y	2005	ALL	Body	Head Up Display																																																												
Y	2005	ALL	Body	HVAC Control Module																																																												
Y	2005	ALL	Body	Instrument Panel Cluster																																																												
Y	2005	ALL	Body	Navigation Radio																																																												
Y	2005	ALL	Body	Passenger Door Module																																																												
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2005	ALL	Body	Steering Column Lock Module																																																												
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2006	(YV)XLR	Powertrain	Engine Control Module																																																												
Y	2006	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																												
Y	2006	(YV)XLR	Powertrain	Automatic Transmission																																																												
Y	2006	(YV)XLR	Chassis	Electronic Brake Control Module																																																												
Y	2006	(YV)XLR	Chassis	Electronic Suspension Control																																																												
Y	2006	(YV)XLR	Chassis	Steering Wheel and Column																																																												
Y	2006	(YV)XLR	Body	Amplifier (Bose)																																																												
Y	2006	(YV)XLR	Body	Body Control Module																																																												V
Y	2006	(YV)XLR	Body	CD Changer																																																												
Y	2006	(YV)XLR	Body	Digital Radio Receiver																																																												
Y	2006	(YV)XLR	Body	Distance Sensing Cruise Control																																																												
Y	2006	(YV)XLR	Body	Driver Door Module																																																												
Y	2006	(YV)XLR	Body	Driver Door Switch																																																												
Y	2006	(YV)XLR	Body	Driver Position Module																																																												
Y	2006	(YV)XLR	Body	Folding Top Module																																																												

| Engine type | Year | Model | System 1 | System 2 | New Actuator Setup Procedure | VSCM Data | Signal Data | VSCM Disable Reason | VSCM Power Steering Reset | Range Measurements | Module Data | Inhibit Data | Calibrate Module | Exh. Aftertreatment Data | Parking Brake Shoe Service Reset | Parking Brake Actuator DTC Reset | Parking Brake Switch Procedure | Charging Info | RVS Disable 1 History | RVS Disable 2 History | RVS Disable 3 History | RVS Disable 4 History | RVS Disable 5 History | RVS Disable 6 History | RVS Disable 7 History | Passenger presence system learn | Signal Type | Module ID Information | Open History Data | Close History Data | Last Open Fail Data | Last Close Fail Data | Obstacle Detect Opening Data | Obstacle Detect Closing Data | LGM Open/Close Test | Deployment Loop 1-14 Resistance | Deployment Loop 15-18 Resistance | Deployment Loop Configuration | Sensor Configuration | Parking Brake Calibration | CAN Bus Communication | Remote Vehicle Start Data | Remote Vehicle Start Disable History 1 Data | Remote Vehicle Start Disable History 2 Data | Remote Vehicle Start Disable History 3 Data | Remote Vehicle Start Disable History 4 Data | Remote Vehicle Start Disable History 5 Data | Remote Vehicle Start Disable History 6 Data | Remote Vehicle Start Disable History 7 Data | Steering Wheel Control Switches | Vehicle Access | Passenger Presence Data | HVAC Door Position Data | A/C Permission Data | Last Liftgate Close Malfunction Data | Last Liftgate Open Malfunction Data | Engineering Data 1 | Engineering Data 2 | Seat Position Data | Steering Column Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Y	2007	(YV)XLR	Body	Navigation Radio																																																													
Y	2007	(YV)XLR	Body	Passenger Door Module																																																													
Y	2007	(YV)XLR	Body	Remote Control Door Lock Receiver																																																													
Y	2007	(YV)XLR	Body	Steering Column Lock Module																																																													
Y	2007	(YV)XLR	Body	Supplemental Inflatable Restraint																																																													
Y	2007	(YX)XLR-V	Powertrain	Engine Control Module																																																													
Y	2007	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																													
Y	2007	(YX)XLR-V	Powertrain	Transmission Control Module																																																													
Y	2007	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																													
Y	2007	(YX)XLR-V	Chassis	Electronic Suspension Control																																																													
Y	2007	(YX)XLR-V	Body	Amplifier (Bose)																																																													
Y	2007	(YX)XLR-V	Body	Body Control Module																																																													V
Y	2007	(YX)XLR-V	Body	CD Changer																																																													
Y	2007	(YX)XLR-V	Body	Digital Radio Receiver																																																												
Y	2007	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																												
Y	2007	(YX)XLR-V	Body	Driver Door Module																																																												
Y	2007	(YX)XLR-V	Body	Driver Door Switch																																																												
Y	2007	(YX)XLR-V	Body	Driver Position Module																																																												
Y	2007	(YX)XLR-V	Body	Folding Top Module																																																												
Y	2007	(YX)XLR-V	Body	Headlamp Control Module																																																												
Y	2007	(YX)XLR-V	Body	Head Up Display																																																												
Y	2007	(YX)XLR-V	Body	HVAC Control Module																																																												
Y	2007	(YX)XLR-V	Body	Instrument Panel Cluster																																																												
Y	2007	(YX)XLR-V	Body	Navigation Radio																																																												
Y	2007	(YX)XLR-V	Body	Passenger Door Module																																																												
Y	2007	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																																												
Y	2007	(YX)XLR-V	Body	Steering Column Lock Module																																																												
Y	2007	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																												
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																												
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																												
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																												
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2008	ALL	Chassis	Electronic Suspension Control																																																												
Y	2008	ALL	Body	Amplifier (Bose)																																																												
Y	2008	ALL	Body	Body Control Module																																																												V
Y	2008	ALL	Body	CD Changer																																																												
Y	2008	ALL	Body	Digital Radio Receiver																																																												
Y	2008	ALL	Body	Distance Sensing Cruise Control																																																												
Y	2008	ALL	Body	Driver Door Module																																																												
Y	2008	ALL	Body	Driver Door Switch																																																												
Y	2008	ALL	Body	Driver Position Module																																																												
Y	2008	ALL	Body	Folding Top Module																																																												
Y	2008	ALL	Body	Headlamp Control Module																																																												
Y	2008	ALL	Body	Head Up Display																																																												
Y	2008	ALL	Body	HVAC Control Module																																																												
Y	2008	ALL	Body	Instrument Panel Cluster																																																												
Y	2008	ALL	Body	Navigation Radio																																																												
Y	2008	ALL	Body	Passenger Door Module																																																												
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Y	2008	ALL	Body	Steering Column Lock Module																																																																
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																																
Y	2008	ALL	Body	Vehicle Comm. Interface Module																																																																
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module										V																																																					
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																																
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																																
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module										V																																																					
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																																
Y	2009	ALL	Chassis	Electronic Brake Control Module			V																																																													
Y	2009	ALL	Chassis	Electronic Suspension Control																																																																
Y	2009	ALL	Body	Amplifier (Bose)																																																																
Y	2009	ALL	Body	Body Control Module																																																																V
Y	2009	ALL	Body	CD Changer																																																																
Y	2009	ALL	Body	Digital Radio Receiver																																																																
Y	2009	ALL	Body	Distance Sensing Cruise Control																																																																
Y	2009	ALL	Body	Driver Door Module																																																																
Y	2009	ALL	Body	Driver Door Switch																																																																
Y	2009	ALL	Body	Driver Position Module																																																																
Y	2009	ALL	Body	Folding Top Module																																																																
Y	2009	ALL	Body	Headlamp Control Module																																																																
Y	2009	ALL	Body	Head Up Display																																																																
Y	2009	ALL	Body	HVAC Control Module																																																																
Y	2009	ALL	Body	Instrument Panel Cluster																																																																
Y	2009	ALL	Body	Navigation Radio																																																																
Y	2009	ALL	Body	Passenger Door Module																																																																
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																																																
Y	2009	ALL	Body	Steering Column Lock Module																																																																
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																																
1	2013	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																																
1	2013	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																																
1	2013	XTS	Powertrain	Fuel Pump Control Module																																																																
1	2013	XTS	Powertrain	Rear Differential Clutch Control Module																																																																
1	2013	XTS	Chassis	Electronic Brake Control Module																																																																
1	2013	XTS	Chassis	Parking Brake Control Module																																																																
1	2013	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																																
1	2013	XTS	Chassis	Power Steering Control Module																																																																
1	2013	XTS	Chassis	Steering Wheel Angle Sensor Module																																																																
1	2013	XTS	Chassis	Suspension Control Module																																																																
1	2013	XTS	Body	Body Control Module																																																																
1	2013	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
1	2013	XTS	Body	Passenger Presence Module																																																																
1	2013	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																																
1	2013	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																																
1	2013	XTS	Body	Radio/HVAC Control																																																																
1	2013	XTS	Body	Active Safety Control Module																																																																
1	2013	XTS	Body	Headlamp Control Module																																																																
1	2013	XTS	Body	Radio																																																																
1	2013	XTS	Body	Amplifier																																																																
1	2013	XTS	Body	Human Machine Interface Control Module																																																																
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 9																																																																
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 10																																																																

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2013	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
1	2013	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																													
1	2013	XTS	Body	Seat Memory Control Module																																																													
1	2013	XTS	Body	Keyless Entry Control Module																																																												
1	2013	XTS	Body	Right Side Object Detection Control Module																																																												
1	2013	XTS	Body	Left Side Object Detection Control Module																																																												
1	2013	XTS	Body	Parking Assist Control Module																																																												
1	2013	XTS	Body	Frontview Camera Module																																																												
1	2013	XTS	Body	Long Range Radar Sensor Module																																																												
1	2013	XTS	Body	Left Front Short Range Radar Sensor Module																																																												
1	2013	XTS	Body	Right Front Short Range Radar Sensor Module																																																												
1	2013	XTS	Body	Rear Short Range Radar Sensor Module																																																												
1	2014	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																												
1	2014	XTS	Powertrain	(8) 3.6L LF3 Chassis Control Module																																																												
1	2014	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																												
1	2014	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
1	2014	XTS	Powertrain	(3) 3.6L LFX Chassis Control Module																																																												
1	2014	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
1	2014	XTS	Powertrain	Rear Differential Clutch Control Module																																																												
1	2014	XTS	Chassis	Electronic Brake Control Module																																																												
1	2014	XTS	Chassis	Parking Brake Control Module																																																												
1	2014	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2014	XTS	Chassis	Power Steering Control Module																																																												
1	2014	XTS	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2014	XTS	Chassis	Suspension Control Module																																																												
1	2014	XTS	Body	Body Control Module																																																												
1	2014	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	XTS	Body	Passenger Presence Module																																																												
1	2014	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
1	2014	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
1	2014	XTS	Body	Radio/HVAC Control																																																												
1	2014	XTS	Body	Active Safety Control Module																																																												
1	2014	XTS	Body	Headlamp Control Module																																																												
1	2014	XTS	Body	Radio																																																												
1	2014	XTS	Body	Amplifier																																																												
1	2014	XTS	Body	Media Disc Player																																																												
1	2014	XTS	Body	Human Machine Interface Control Module																																																												
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2014	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
1	2014	XTS	Body	Seat Memory Control Module - Passenger																																																												
1	2014	XTS	Body	Seat Memory Control Module - Driver																																																												
1	2014	XTS	Body	Keyless Entry Control Module																																																												
1	2014	XTS	Body	Right Side Object Detection Control Module																																																												
1	2014	XTS	Body	Left Side Object Detection Control Module																																																												
1	2014	XTS	Body	Parking Assist Control Module																																																												
1	2014	XTS	Body	Frontview Camera Module																																																												
1	2014	XTS	Body	Long Range Radar Sensor Module																																																												
1	2014	XTS	Body	Left Front Short Range Radar Sensor Module																																																												
1	2014	XTS	Body	Right Front Short Range Radar Sensor Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2014	XTS	Body	Rear Short Range Radar Sensor Module																																																												
1	2015	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																												
1	2015	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																												
1	2015	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
1	2015	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
1	2015	XTS	Powertrain	Chassis Control Module																																																												
1	2015	XTS	Powertrain	Rear Differential Clutch Control Module																																																												
1	2015	XTS	Chassis	Electronic Brake Control Module																																																												
1	2015	XTS	Chassis	Parking Brake Control Module																																																												
1	2015	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2015	XTS	Chassis	Power Steering Control Module																																																												
1	2015	XTS	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2015	XTS	Chassis	Suspension Control Module																																																												
1	2015	XTS	Body	Body Control Module																																																												
1	2015	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2015	XTS	Body	Passenger Presence Module																																																												
1	2015	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
1	2015	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
1	2015	XTS	Body	Radio/HVAC Control																																																												
1	2015	XTS	Body	Active Safety Control Module																																																												
1	2015	XTS	Body	Radio																																																												
1	2015	XTS	Body	Amplifier																																																												
1	2015	XTS	Body	Media Disc Player																																																												
1	2015	XTS	Body	Human Machine Interface Control Module																																																												
1	2015	XTS	Body	Telematics Communication Interface Control Module																																																												
1	2015	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2015	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
1	2015	XTS	Body	Seat Memory Control Module - Passenger																																																												
1	2015	XTS	Body	Seat Memory Control Module - Driver																																																												
1	2015	XTS	Body	Keyless Entry Control Module																																																												
1	2015	XTS	Body	Right Side Object Detection Control Module																																																												
1	2015	XTS	Body	Left Side Object Detection Control Module																																																												
1	2015	XTS	Body	Parking Assist Control Module GMLAN																																																												
1	2015	XTS	Body	Parking Assist Control Module DID72History																																																												
1	2015	XTS	Body	Frontview Camera Module																																																												
1	2015	XTS	Body	Long Range Radar Sensor Module																																																												
1	2015	XTS	Body	Left Front Short Range Radar Sensor Module																																																												
1	2015	XTS	Body	Right Front Short Range Radar Sensor Module																																																												
1	2015	XTS	Body	Rear Short Range Radar Sensor Module																																																												
1	2016	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																												
1	2016	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																												
1	2016	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
1	2016	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
1	2016	XTS	Powertrain	Chassis Control Module																																																												
1	2016	XTS	Powertrain	Rear Differential Clutch Control Module																																																												
1	2016	XTS	Chassis	Electronic Brake Control Module																																																												
1	2016	XTS	Chassis	Parking Brake Control Module																																																												
1	2016	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2016	XTS	Chassis	Power Steering Control Module																																																												
1	2016	XTS	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2016	XTS	Chassis	Suspension Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2016	XTS	Body	Body Control Module																																																														
1	2016	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
1	2016	XTS	Body	Passenger Presence Module																																																														
1	2016	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																														
1	2016	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																														
1	2016	XTS	Body	Radio/HVAC Control																																																														
1	2016	XTS	Body	Active Safety Control Module																																																														
1	2016	XTS	Body	Video Processing Control Module																																																														
1	2016	XTS	Body	Radio																																																														
1	2016	XTS	Body	Amplifier																																																														
1	2016	XTS	Body	Media Disc Player																																																														
1	2016	XTS	Body	Human Machine Interface Control Module																																																														
1	2016	XTS	Body	Telematics Communication Interface Control Module																																																														
1	2016	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
1	2016	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																														
1	2016	XTS	Body	Seat Memory Control Module - Passenger																																																														
1	2016	XTS	Body	Seat Memory Control Module - Driver																																																														
1	2016	XTS	Body	Keyless Entry Control Module																																																														
1	2016	XTS	Body	Right Side Object Detection Control Module																																																														
1	2016	XTS	Body	Left Side Object Detection Control Module																																																														
1	2016	XTS	Body	Parking Assist Control Module																																																														
1	2016	XTS	Body	Frontview Camera Module																																																														
1	2016	XTS	Body	Steering Column Lock Control Module																																																														
1	2016	XTS	Body	Long Range Radar Sensor Module																																																														
1	2016	XTS	Body	Left Front Short Range Radar Sensor Module																																																														
1	2016	XTS	Body	Right Front Short Range Radar Sensor Module																																																														
1	2016	XTS	Body	Rear Short Range Radar Sensor Module																																																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																									
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																									
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump																																																									
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																									
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Engine Mount																																																									
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																									
A	2013	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																									
A	2013	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																									
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump																																																									
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																									
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Engine Mount																																																									
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																									
A	2013	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump																																																									
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																									
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Engine Mount																																																									
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																									
A	2013	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
A	2013	ATS	Powertrain	Transfer Case Control Module																																																										
A	2013	ATS	Chassis	Electronic Brake Control Module																																																									
A	2013	ATS	Chassis	Parking Brake Control Module																																																									
A	2013	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2013	ATS	Chassis	Power Steering Control Module																																																									
A	2013	ATS	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2013	ATS	Chassis	Suspension Control Module																																																									
A	2013	ATS	Body	Body Control Module Halogen																																																									
A	2013	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
A	2013	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2013	ATS	Body	Passenger Presence Module																																																									
A	2013	ATS	Body	Pedestrian Impact Detection Module																																																									
A	2013	ATS	Body	Instrument Cluster																																																									
A	2013	ATS	Body	Radio/HVAC Control																																																									
A	2013	ATS	Body	Active Safety Control Module																																																									
A	2013	ATS	Body	Headlamp Control Module																																																									
A	2013	ATS	Body	Trailer Interface Control Module																																																									
A	2013	ATS	Body	Radio																																																									
A	2013	ATS	Body	Amplifier																																																									
A	2013	ATS	Body	Human Machine Interface Control Module																																																									
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 9																																																									
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2013	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
A	2013	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																									
A	2013	ATS	Body	Seat Memory Control Module																																																									
A	2013	ATS	Body	Keyless Entry Type Without Passive Entry																																																									
A	2013	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
A	2013	ATS	Body	Right Side Object Detection Control Module																																																									
A	2013	ATS	Body	Left Side Object Detection Control Module																																																									
A	2013	ATS	Body	Parking Assist Control Module																																																									
A	2013	ATS	Body	Frontview Camera Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2013	ATS	Body	Steering Column Lock Control Module																																																									
A	2013	ATS	Body	Long Range Radar Sensor Module																																																										
A	2013	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2013	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2013	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2014	ATS	Powertrain	Transfer Case Control Module																																																										
A	2014	ATS	Chassis	Electronic Brake Control Module																																																										
A	2014	ATS	Chassis	Parking Brake Control Module																																																										
A	2014	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	ATS	Chassis	Power Steering Control Module																																																										
A	2014	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	ATS	Chassis	Suspension Control Module																																																										
A	2014	ATS	Body	Body Control Module Halogen																																																										
A	2014	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2014	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	ATS	Body	Passenger Presence Module																																																										
A	2014	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2014	ATS	Body	Instrument Cluster																																																										
A	2014	ATS	Body	Radio/HVAC Control																																																										
A	2014	ATS	Body	Active Safety Control Module																																																										
A	2014	ATS	Body	Headlamp Control Module																																																										
A	2014	ATS	Body	Trailer Interface Control Module																																																										
A	2014	ATS	Body	Radio																																																										
A	2014	ATS	Body	Amplifier																																																										
A	2014	ATS	Body	Media Disc Player																																																										
A	2014	ATS	Body	Human Machine Interface Control Module																																																										
A	2014	ATS	Body	Navigation Control Module																																																										
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2014	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2014	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2014	ATS	Body	Seat Memory Control Module - Driver																																																										
A	2014	ATS	Body	Keyless Entry Type Without Passive Entry																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2014	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
A	2014	ATS	Body	Right Side Object Detection Control Module																																																											
A	2014	ATS	Body	Left Side Object Detection Control Module																																																											
A	2014	ATS	Body	Parking Assist Control Module																																																											
A	2014	ATS	Body	Frontview Camera Module																																																											
A	2014	ATS	Body	Steering Column Lock Control Module																																																											
A	2014	ATS	Body	Long Range Radar Sensor Module																																																											
A	2014	ATS	Body	Left Front Short Range Radar Sensor Module																																																											
A	2014	ATS	Body	Right Front Short Range Radar Sensor Module																																																											
A	2014	ATS	Body	Rear Short Range Radar Sensor Module																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Maunal Transmission																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2014	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
A	2014	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
A	2014	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																											
A	2014	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
A	2014	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2014	CTS	Powertrain	Transfer Case Control Module																																																											
A	2014	CTS	Chassis	Electronic Brake Control Module																																																											
A	2014	CTS	Chassis	Parking Brake Control Module																																																											
A	2014	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2014	CTS	Chassis	Power Steering Control Module																																																											
A	2014	CTS	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2014	CTS	Chassis	Suspension Control Module																																																											
A	2014	CTS	Body	Body Control Module Headlamp Type Halogen																																																											
A	2014	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
A	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2014	CTS	Body	Passenger Presence Module																																																											
A	2014	CTS	Body	Pedestrian Impact Detection Module																																																											
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Left																																																											
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Right																																																											
A	2014	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
A	2014	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																											
A	2014	CTS	Body	Radio/HVAC Control																																																											
A	2014	CTS	Body	Active Safety Control Module																																																											
A	2014	CTS	Body	Headlamp Control Module																																																											
A	2014	CTS	Body	Trailer Interface Control Module																																																											
A	2014	CTS	Body	Radio																																																											
A	2014	CTS	Body	Amplifier																																																										
A	2014	CTS	Body	Human Machine Interface Control Module																																																											
A	2014	CTS	Body	Navigation Control Module																																																											
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2014	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2014	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2014	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2014	CTS	Body	Keyless Entry Control Module																																																										
A	2014	CTS	Body	Right Side Object Detection Control Module																																																										
A	2014	CTS	Body	Left Side Object Detection Control Module																																																										
A	2014	CTS	Body	Parking Assist Control Module																																																										
A	2014	CTS	Body	Frontview Camera Module																																																										
A	2014	CTS	Body	Steering Column Lock Control Module																																																										
A	2014	CTS	Body	Long Range Radar Sensor Module																																																										
A	2014	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2014	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2014	CTS	Body	Rear Short Range Radar Sensor Module																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2015	ATS	Powertrain	Transfer Case Control Module																																																										
A	2015	ATS	Chassis	Electronic Brake Control Module																																																										
A	2015	ATS	Chassis	Parking Brake Control Module																																																										
A	2015	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	ATS	Chassis	Power Steering Control Module																																																										
A	2015	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	ATS	Chassis	Suspension Control Module																																																										
A	2015	ATS	Body	Body Control Module Halogen																																																										
A	2015	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2015	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	ATS	Body	Passenger Presence Module																																																										
A	2015	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2015	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2015	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2015	ATS	Body	Radio/HVAC Control																																																										
A	2015	ATS	Body	Active Safety Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2015	ATS	Body	Headlamp Control Module																																																										
A	2015	ATS	Body	Trailer Interface Control Module																																																											
A	2015	ATS	Body	Radio																																																										
A	2015	ATS	Body	Amplifier																																																										
A	2015	ATS	Body	Media Disc Player																																																										
A	2015	ATS	Body	Human Machine Interface Control Module																																																										
A	2015	ATS	Body	Navigation Control Module																																																										
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2015	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2015	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2015	ATS	Body	Seat Memory Control Module - Driver																																																										
A	2015	ATS	Body	Keyless Entry Control Module Coupe																																																										
A	2015	ATS	Body	Keyless Entry Control Module Sadan																																																										
A	2015	ATS	Body	Right Side Object Detection Control Module																																																										
A	2015	ATS	Body	Left Side Object Detection Control Module																																																										
A	2015	ATS	Body	Parking Assist Control Module																																																										
A	2015	ATS	Body	Frontview Camera Module																																																										
A	2015	ATS	Body	Steering Column Lock Control Module																																																										
A	2015	ATS	Body	Long Range Radar Sensor Module																																																										
A	2015	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2015	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2015	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Engine Mount																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Engine Mount																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																										
A	2015	CTS	Powertrain	Transfer Case Control Module																																																										
A	2015	CTS	Chassis	Electronic Brake Control Module																																																										
A	2015	CTS	Chassis	Parking Brake Control Module																																																										
A	2015	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	CTS	Chassis	Power Steering Control Module																																																										
A	2015	CTS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	CTS	Chassis	Suspension Control Module																																																										
A	2015	CTS	Body	Body Control Module Headlamp Type Halogen																																																										
A	2015	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	CTS	Body	Passenger Presence Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2015	CTS	Body	Pedestrian Impact Detection Module																																																										
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2015	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2015	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2015	CTS	Body	Active Safety Control Module																																																										
A	2015	CTS	Body	Trailer Interface Control Module																																																										
A	2015	CTS	Body	Radio																																																										
A	2015	CTS	Body	Amplifier																																																										
A	2015	CTS	Body	Human Machine Interface Control Module																																																										
A	2015	CTS	Body	Navigation Control Module																																																										
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2015	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2015	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2015	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2015	CTS	Body	Keyless Entry Control Module																																																										
A	2015	CTS	Body	Right Side Object Detection Control Module																																																										
A	2015	CTS	Body	Left Side Object Detection Control Module																																																										
A	2015	CTS	Body	Parking Assist Control Module																																																										
A	2015	CTS	Body	Frontview Camera Module																																																										
A	2015	CTS	Body	Steering Column Lock Control Module																																																										
A	2015	CTS	Body	Long Range Radar Sensor Module																																																										
A	2015	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2015	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2015	CTS	Body	Rear Short Range Radar Sensor Module																																																										
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2016	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
A	2016	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Automatic Transmission																																																										
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Manual Transmission																																																										
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Transmission Control Module																																																										
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																										
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																										
A	2016	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2016	ATS	Powertrain	Transfer Case Control Module																																																										
A	2016	ATS	Powertrain	Rear Differential Clutch Control Module																																																										
A	2016	ATS	Chassis	Electronic Brake Control Module																																																										
A	2016	ATS	Chassis	Parking Brake Control Module																																																										
A	2016	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2016	ATS	Chassis	Power Steering Control Module																																																										
A	2016	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	ATS	Chassis	Suspension Control Module																																																										
A	2016	ATS	Body	Body Control Module Halogen																																																										
A	2016	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2016	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	ATS	Body	Passenger Presence Module																																																										
A	2016	ATS	Body	Pedestrian Impact Detection Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2016	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2016	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2016	ATS	Body	Radio/HVAC Control																																																										
A	2016	ATS	Body	Vehicle Performance Data Recorder																																																										
A	2016	ATS	Body	Trailer Interface Control Module																																																										
A	2016	ATS	Body	Radio																																																										
A	2016	ATS	Body	Amplifier																																																										
A	2016	ATS	Body	Rear Audio Control Module																																																										
A	2016	ATS	Body	Media Disc Player																																																										
A	2016	ATS	Body	Human Machine Interface Control Module																																																										
A	2016	ATS	Body	Navigation Control Module																																																										
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2016	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2016	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2016	ATS	Body	Seat Memory Control Module - Passenger																																																										
A	2016	ATS	Body	Seat Memory Control Module - Driver																																																										
A	2016	ATS	Body	Keyless Entry Control Module Coupe																																																										
A	2016	ATS	Body	Keyless Entry Control Module Sadan																																																										
A	2016	ATS	Body	Right Side Object Detection Control Module																																																										
A	2016	ATS	Body	Left Side Object Detection Control Module																																																										
A	2016	ATS	Body	Parking Assist Control Module																																																										
A	2016	ATS	Body	Frontview Camera Module																																																										
A	2016	ATS	Body	Steering Column Lock Control Module																																																										
A	2016	ATS	Body	Long Range Radar Sensor Module																																																										
A	2016	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2016	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2016	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2016	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
A	2016	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2016	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
A	2016	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
A	2016	CTS	Powertrain	(S) 3.6L LGX Engine Control Module																																																										
A	2016	CTS	Powertrain	(S) 3.6L LGX Transmission Control Module																																																										
A	2016	CTS	Powertrain	(6) 6.2L LT4 Engine Control Module																																																										
A	2016	CTS	Powertrain	(6) 6.2L LT4 Transmission Control Module																																																										
A	2016	CTS	Powertrain	Rear Differential Clutch Control Module																																																										
A	2016	CTS	Powertrain	Transfer Case Control Module																																																										
A	2016	CTS	Chassis	Electronic Brake Control Module																																																										
A	2016	CTS	Chassis	Parking Brake Control Module																																																										
A	2016	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2016	CTS	Chassis	Power Steering Control Module																																																										
A	2016	CTS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	CTS	Chassis	Suspension Control Module																																																										
A	2016	CTS	Body	Body Control Module Headlamp Type Halogen																																																										
A	2016	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2016	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	CTS	Body	Passenger Presence Module																																																										
A	2016	CTS	Body	Pedestrian Impact Detection Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2016	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2016	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2016	CTS	Body	Radio/HVAC Control																																																										
A	2016	CTS	Body	Vehicle Performance Data Recorder																																																										
A	2016	CTS	Body	Active Safety Control Module																																																										
A	2016	CTS	Body	Video Processing Control Module																																																										
A	2016	CTS	Body	Trailer Interface Control Module																																																										
A	2016	CTS	Body	Radio																																																										
A	2016	CTS	Body	Amplifier																																																									
A	2016	CTS	Body	Human Machine Interface Control Module																																																										
A	2016	CTS	Body	Navigation Control Module																																																										
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2016	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2016	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2016	CTS	Body	Seat Memory Control Module - Passenger																																																										
A	2016	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2016	CTS	Body	Keyless Entry Control Module																																																										
A	2016	CTS	Body	Right Side Object Detection Control Module																																																										
A	2016	CTS	Body	Left Side Object Detection Control Module																																																										
A	2016	CTS	Body	Parking Assist Control Module																																																										
A	2016	CTS	Body	Frontview Camera Module																																																										
A	2016	CTS	Body	Steering Column Lock Control Module																																																										
A	2016	CTS	Body	Long Range Radar Sensor Module																																																										
A	2016	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2016	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2016	CTS	Body	Rear Short Range Radar Sensor Module																																																										
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																										
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																										
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																										
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																										
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																										
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																										
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2004	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2004	(DM)CTS	Chassis	VES																																																										
D	2004	(DM)CTS	Body	Amplifier (Bose)																																																										
D	2004	(DM)CTS	Body	Amplifier (Delco)																																																										
D	2004	(DM)CTS	Body	Climate Control Panel																																																										
D	2004	(DM)CTS	Body	Dash Integration Module																																																										
D	2004	(DM)CTS	Body	Digital Radio Receiver																																																										
D	2004	(DM)CTS	Body	Driver Door Switch																																																										
D	2004	(DM)CTS	Body	Driver Door Module																																																										
D	2004	(DM)CTS	Body	Passenger Door Module																																																										
D	2004	(DM)CTS	Body	Left Rear Door Module																																																										
D	2004	(DM)CTS	Body	Right Rear Door Module																																																										
D	2004	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2004	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2004	(DM)CTS	Body	Instrument Panel Cluster																																																											
D	2004	(DM)CTS	Body	Memory Seat Module																																																												
D	2004	(DM)CTS	Body	Personalization																																																												
D	2004	(DM)CTS	Body	Rear Integration Module																																																												
D	2004	(DM)CTS	Body	Remote Function Actuation																																																												
D	2004	(DM)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2004	(DM)CTS	Body	TV Antenna Module																																																												
D	2004	(DM)CTS	Body	Vehicle Theft Deterrent																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																												
D	2004	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2004	(DR)CTS	Chassis	VES																																																												
D	2004	(DR)CTS	Body	Amplifier (Bose)																																																												
D	2004	(DR)CTS	Body	Amplifier (Delco)																																																												
D	2004	(DR)CTS	Body	Climate Control Panel																																																												
D	2004	(DR)CTS	Body	Dash Integration Module																																																												
D	2004	(DR)CTS	Body	Digital Radio Receiver																																																												
D	2004	(DR)CTS	Body	Driver Door Switch																																																												
D	2004	(DR)CTS	Body	Driver Door Module																																																												
D	2004	(DR)CTS	Body	Passenger Door Module																																																												
D	2004	(DR)CTS	Body	Left Rear Door Module																																																												
D	2004	(DR)CTS	Body	Right Rear Door Module																																																												
D	2004	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2004	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2004	(DR)CTS	Body	Instrument Panel Cluster																																																												
D	2004	(DR)CTS	Body	Memory Seat Module																																																												
D	2004	(DR)CTS	Body	Personalization																																																												
D	2004	(DR)CTS	Body	Rear Integration Module																																																												
D	2004	(DR)CTS	Body	Remote Function Actuation																																																												
D	2004	(DR)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2004	(DR)CTS	Body	TV Antenna Module																																																												
D	2004	(DR)CTS	Body	Vehicle Theft Deterrent																																																												
D	2004	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																												
D	2004	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																												
D	2004	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																												
D	2004	(DN)CTS-V	Chassis	VES																																																												
D	2004	(DN)CTS-V	Body	Amplifier (Bose)																																																												
D	2004	(DN)CTS-V	Body	Amplifier (Delco)																																																												
D	2004	(DN)CTS-V	Body	Climate Control Panel																																																												
D	2004	(DN)CTS-V	Body	Dash Integration Module																																																												
D	2004	(DN)CTS-V	Body	Digital Radio Receiver																																																												
D	2004	(DN)CTS-V	Body	Driver Door Switch																																																												
D	2004	(DN)CTS-V	Body	Driver Door Module																																																												
D	2004	(DN)CTS-V	Body	Passenger Door Module																																																												
D	2004	(DN)CTS-V	Body	Left Rear Door Module																																																												
D	2004	(DN)CTS-V	Body	Right Rear Door Module																																																												
D	2004	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2004	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																										
D	2004	(DN)CTS-V	Body	Instrument Panel Cluster																																																										
D	2004	(DN)CTS-V	Body	Memory Seat Module																																																										
D	2004	(DN)CTS-V	Body	Personalization																																																										
D	2004	(DN)CTS-V	Body	Rear Integration Module																																																										
D	2004	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																										
D	2004	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																										
D	2004	(DN)CTS-V	Body	TV Antenna Module																																																										
D	2004	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																										
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2005	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2005	(DM)CTS	Chassis	VES																																																										
D	2005	(DM)CTS	Body	Amplifier (Bose)																																																										
D	2005	(DM)CTS	Body	Amplifier (Delco)																																																										
D	2005	(DM)CTS	Body	Climate Control Panel																																																										
D	2005	(DM)CTS	Body	Dash Integration Module																																																										
D	2005	(DM)CTS	Body	Digital Radio Receiver																																																										
D	2005	(DM)CTS	Body	Driver Door Switch																																																										
D	2005	(DM)CTS	Body	Driver Door Module																																																										
D	2005	(DM)CTS	Body	Passenger Door Module																																																										
D	2005	(DM)CTS	Body	Left Rear Door Module																																																										
D	2005	(DM)CTS	Body	Right Rear Door Module																																																										
D	2005	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2005	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2005	(DM)CTS	Body	Instrument Panel Cluster																																																										
D	2005	(DM)CTS	Body	Memory Seat Module																																																										
D	2005	(DM)CTS	Body	Personalization																																																										
D	2005	(DM)CTS	Body	Rear Integration Module																																																										
D	2005	(DM)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DM)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DM)CTS	Body	TV Antenna Module																																																										
D	2005	(DM)CTS	Body	Vehicle Theft Deterrent																																																										
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2005	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2005	(DP)CTS	Chassis	VES																																																										
D	2005	(DP)CTS	Body	Amplifier (Bose)																																																										
D	2005	(DP)CTS	Body	Amplifier (Delco)																																																										
D	2005	(DP)CTS	Body	Climate Control Panel																																																										
D	2005	(DP)CTS	Body	Dash Integration Module																																																										
D	2005	(DP)CTS	Body	Digital Radio Receiver																																																										
D	2005	(DP)CTS	Body	Driver Door Switch																																																										
D	2005	(DP)CTS	Body	Driver Door Module																																																										
D	2005	(DP)CTS	Body	Passenger Door Module																																																										
D	2005	(DP)CTS	Body	Left Rear Door Module																																																										
D	2005	(DP)CTS	Body	Right Rear Door Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2005	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2005	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2005	(DP)CTS	Body	Instrument Panel Cluster																																																										
D	2005	(DP)CTS	Body	Memory Seat Module																																																										
D	2005	(DP)CTS	Body	Personalization																																																										
D	2005	(DP)CTS	Body	Rear Integration Module																																																										
D	2005	(DP)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DP)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DP)CTS	Body	TV Antenna Module																																																										
D	2005	(DP)CTS	Body	Vehicle Theft Deterrent																																																										
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2005	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2005	(DR)CTS	Chassis	VES																																																										
D	2005	(DR)CTS	Body	Amplifier (Bose)																																																										
D	2005	(DR)CTS	Body	Amplifier (Delco)																																																										
D	2005	(DR)CTS	Body	Climate Control Panel																																																										
D	2005	(DR)CTS	Body	Dash Integration Module																																																										
D	2005	(DR)CTS	Body	Digital Radio Receiver																																																										
D	2005	(DR)CTS	Body	Driver Door Switch																																																										
D	2005	(DR)CTS	Body	Driver Door Module																																																										
D	2005	(DR)CTS	Body	Passenger Door Module																																																										
D	2005	(DR)CTS	Body	Left Rear Door Module																																																										
D	2005	(DR)CTS	Body	Right Rear Door Module																																																										
D	2005	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2005	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2005	(DR)CTS	Body	Instrument Panel Cluster																																																										
D	2005	(DR)CTS	Body	Memory Seat Module																																																										
D	2005	(DR)CTS	Body	Personalization																																																										
D	2005	(DR)CTS	Body	Radio																																																										
D	2005	(DR)CTS	Body	Rear Integration Module																																																										
D	2005	(DR)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DR)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DR)CTS	Body	TV Antenna Module																																																										
D	2005	(DR)CTS	Body	Vehicle Theft Deterrent																																																										
D	2005	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																										
D	2005	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																										
D	2005	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																										
D	2005	(DN)CTS-V	Chassis	VES																																																										
D	2005	(DN)CTS-V	Body	Amplifier (Bose)																																																										
D	2005	(DN)CTS-V	Body	Amplifier (Delco)																																																										
D	2005	(DN)CTS-V	Body	Climate Control Panel																																																										
D	2005	(DN)CTS-V	Body	Dash Integration Module																																																										
D	2005	(DN)CTS-V	Body	Digital Radio Receiver																																																										
D	2005	(DN)CTS-V	Body	Driver Door Switch																																																										
D	2005	(DN)CTS-V	Body	Driver Door Module																																																										
D	2005	(DN)CTS-V	Body	Passenger Door Module																																																										
D	2005	(DN)CTS-V	Body	Left Rear Door Module																																																										
D	2005	(DN)CTS-V	Body	Right Rear Door Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2005	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																										
D	2005	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																										
D	2005	(DN)CTS-V	Body	Instrument Panel Cluster																																																										
D	2005	(DN)CTS-V	Body	Memory Seat Module																																																										
D	2005	(DN)CTS-V	Body	Personalization																																																										
D	2005	(DN)CTS-V	Body	Radio																																																										
D	2005	(DN)CTS-V	Body	Rear Integration Module																																																										
D	2005	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DN)CTS-V	Body	TV Antenna Module																																																										
D	2005	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																										
D	2005	(DC)STS-V8	Powertrain	Engine Control Module																																																										
D	2005	(DC)STS-V8	Powertrain	Transmission Control Module																																																										
D	2005	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																										
D	2005	(DC)STS-V8	Chassis	Electronic Suspension Control																																																										
D	2005	(DC)STS-V8	Body	Amplifier (Bose)																																																										
D	2005	(DC)STS-V8	Body	Digital Radio Receiver																																																										
D	2005	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																										
D	2005	(DC)STS-V8	Body	Driver Door Module																																																										
D	2005	(DC)STS-V8	Body	Driver Door Switch																																																										
D	2005	(DC)STS-V8	Body	Driver Position Module																																																										
D	2005	(DC)STS-V8	Body	Headlamp Control Module																																																										
D	2005	(DC)STS-V8	Body	Head Up Display																																																										
D	2005	(DC)STS-V8	Body	HVAC Control Module																																																										
D	2005	(DC)STS-V8	Body	Instrument Panel Cluster																																																										
D	2005	(DC)STS-V8	Body	Instrument Panel Module																																																										
D	2005	(DC)STS-V8	Body	Left Rear Door Module																																																										
D	2005	(DC)STS-V8	Body	Passenger Door Module																																																										
D	2005	(DC)STS-V8	Body	Uplevel Radio																																																										
D	2005	(DC)STS-V8	Body	Navigation Radio																																																										
D	2005	(DC)STS-V8	Body	Rear Integration Module																																																										
D	2005	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DC)STS-V8	Body	Right Rear Door Module																																																										
D	2005	(DC)STS-V8	Body	Steering Column Lock Module																																																										
D	2005	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DC)STS-V8	Body	TV Antenna Module																																																										
D	2005	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																										
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2005	(DW)STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2005	(DW)STS	Chassis	Electronic Brake Control Module																																																										
D	2005	(DW)STS	Chassis	Electronic Suspension Control																																																										
D	2005	(DW)STS	Body	Amplifier (Bose)																																																										
D	2005	(DW)STS	Body	Digital Radio Receiver																																																										
D	2005	(DW)STS	Body	Distance Sensing Cruise Control																																																										
D	2005	(DW)STS	Body	Driver Door Module																																																										
D	2005	(DW)STS	Body	Driver Door Switch																																																										
D	2005	(DW)STS	Body	Driver Position Module																																																										
D	2005	(DW)STS	Body	Headlamp Control Module																																																										
D	2005	(DW)STS	Body	Head Up Display																																																										
D	2005	(DW)STS	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2005	(DW)STS	Body	Instrument Panel Cluster																																																										
D	2005	(DW)STS	Body	Instrument Panel Module																																																											
D	2005	(DW)STS	Body	Left Rear Door Module																																																											
D	2005	(DW)STS	Body	Passenger Door Module																																																											
D	2005	(DW)STS	Body	Uplevel Radio																																																											
D	2005	(DW)STS	Body	Navigation Radio																																																											
D	2005	(DW)STS	Body	Rear Integration Module																																																											
D	2005	(DW)STS	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DW)STS	Body	Right Rear Door Module																																																											
D	2005	(DW)STS	Body	Steering Column Lock Module																																																											
D	2005	(DW)STS	Body	Supplemental Inflatable Restraint																																																											
D	2005	(DW)STS	Body	TV Antenna Module																																																											
D	2005	(DW)STS	Body	Vehicle Comm. Interface Module																																																											
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DM)CTS	Chassis	Tire Pressure Monitor																																																											
D	2006	(DM)CTS	Chassis	VES																																																											
D	2006	(DM)CTS	Body	Amplifier (Bose)																																																											
D	2006	(DM)CTS	Body	Amplifier (Delco)																																																											
D	2006	(DM)CTS	Body	Climate Control Panel																																																											
D	2006	(DM)CTS	Body	Dash Integration Module																																																											
D	2006	(DM)CTS	Body	Digital Radio Receiver																																																											
D	2006	(DM)CTS	Body	Driver Door Switch																																																											
D	2006	(DM)CTS	Body	Driver Door Module																																																											
D	2006	(DM)CTS	Body	Passenger Door Module																																																											
D	2006	(DM)CTS	Body	Left Rear Door Module																																																											
D	2006	(DM)CTS	Body	Right Rear Door Module																																																											
D	2006	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DM)CTS	Body	Instrument Panel Cluster																																																											
D	2006	(DM)CTS	Body	Memory Seat Module																																																											
D	2006	(DM)CTS	Body	Personalization																																																											
D	2006	(DM)CTS	Body	Radio																																																											
D	2006	(DM)CTS	Body	Rear Integration Module																																																											
D	2006	(DM)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DM)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DM)CTS	Body	TV Antenna Module																																																											
D	2006	(DM)CTS	Body	Vehicle Theft Deterrent																																																											
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DP)CTS	Chassis	Tire Pressure Monitor																																																											
D	2006	(DP)CTS	Chassis	VES																																																											
D	2006	(DP)CTS	Body	Amplifier (Bose)																																																											
D	2006	(DP)CTS	Body	Amplifier (Delco)																																																											
D	2006	(DP)CTS	Body	Climate Control Panel																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2006	(DP)CTS	Body	Dash Integration Module																																																											
D	2006	(DP)CTS	Body	Digital Radio Receiver																																																											
D	2006	(DP)CTS	Body	Driver Door Switch																																																											
D	2006	(DP)CTS	Body	Driver Door Module																																																											
D	2006	(DP)CTS	Body	Passenger Door Module																																																											
D	2006	(DP)CTS	Body	Left Rear Door Module																																																											
D	2006	(DP)CTS	Body	Right Rear Door Module																																																											
D	2006	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DP)CTS	Body	Instrument Panel Cluster																																																											
D	2006	(DP)CTS	Body	Memory Seat Module																																																											
D	2006	(DP)CTS	Body	Personalization																																																											
D	2006	(DP)CTS	Body	Radio																																																											
D	2006	(DP)CTS	Body	Rear Integration Module																																																											
D	2006	(DP)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DP)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DP)CTS	Body	TV Antenna Module																																																											
D	2006	(DP)CTS	Body	Vehicle Theft Deterrent																																																											
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DR)CTS	Chassis	Tire Pressure Monitor																																																											
D	2006	(DR)CTS	Chassis	VES																																																											
D	2006	(DR)CTS	Body	Amplifier (Bose)																																																											
D	2006	(DR)CTS	Body	Amplifier (Delco)																																																											
D	2006	(DR)CTS	Body	Climate Control Panel																																																											
D	2006	(DR)CTS	Body	Dash Integration Module																																																											
D	2006	(DR)CTS	Body	Digital Radio Receiver																																																											
D	2006	(DR)CTS	Body	Driver Door Switch																																																											
D	2006	(DR)CTS	Body	Driver Door Module																																																											
D	2006	(DR)CTS	Body	Passenger Door Module																																																											
D	2006	(DR)CTS	Body	Left Rear Door Module																																																											
D	2006	(DR)CTS	Body	Right Rear Door Module																																																											
D	2006	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DR)CTS	Body	Instrument Panel Cluster																																																											
D	2006	(DR)CTS	Body	Memory Seat Module																																																											
D	2006	(DR)CTS	Body	Personalization																																																											
D	2006	(DR)CTS	Body	Radio																																																											
D	2006	(DR)CTS	Body	Rear Integration Module																																																											
D	2006	(DR)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DR)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DR)CTS	Body	TV Antenna Module																																																											
D	2006	(DR)CTS	Body	Vehicle Theft Deterrent																																																											
D	2006	(DN)CTS-V	Powertrain	Engine Control Module																																																											
D	2006	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																											
D	2006	(DN)CTS-V	Chassis	VES																																																											
D	2006	(DN)CTS-V	Body	Amplifier (Bose)																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2006	(DN)CTS-V	Body	Amplifier (Delco)																																																										
D	2006	(DN)CTS-V	Body	Climate Control Panel																																																										
D	2006	(DN)CTS-V	Body	Dash Integration Module																																																										
D	2006	(DN)CTS-V	Body	Digital Radio Receiver																																																										
D	2006	(DN)CTS-V	Body	Driver Door Switch																																																										
D	2006	(DN)CTS-V	Body	Driver Door Module																																																										
D	2006	(DN)CTS-V	Body	Passenger Door Module																																																										
D	2006	(DN)CTS-V	Body	Left Rear Door Module																																																										
D	2006	(DN)CTS-V	Body	Right Rear Door Module																																																										
D	2006	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																										
D	2006	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																										
D	2006	(DN)CTS-V	Body	Instrument Panel Cluster																																																										
D	2006	(DN)CTS-V	Body	Memory Seat Module																																																										
D	2006	(DN)CTS-V	Body	Personalization																																																										
D	2006	(DN)CTS-V	Body	Rear Integration Module																																																										
D	2006	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																										
D	2006	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																										
D	2006	(DN)CTS-V	Body	TV Antenna Module																																																										
D	2006	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																										
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Engine Controls																																																										
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2006	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																										
D	2006	(DC)STS-V8	Chassis	Electronic Suspension Control																																																										
D	2006	(DC)STS-V8	Body	Amplifier (Bose)																																																										
D	2006	(DC)STS-V8	Body	Digital Radio Receiver																																																										
D	2006	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																										
D	2006	(DC)STS-V8	Body	Driver Door Module																																																										
D	2006	(DC)STS-V8	Body	Driver Door Switch																																																										
D	2006	(DC)STS-V8	Body	Driver Position Module																																																										
D	2006	(DC)STS-V8	Body	Headlamp Control Module																																																										
D	2006	(DC)STS-V8	Body	Head Up Display																																																										
D	2006	(DC)STS-V8	Body	HVAC Control Module																																																										
D	2006	(DC)STS-V8	Body	Instrument Panel Cluster																																																										
D	2006	(DC)STS-V8	Body	Instrument Panel Module																																																										
D	2006	(DC)STS-V8	Body	Left Rear Door Module																																																										
D	2006	(DC)STS-V8	Body	Passenger Door Module																																																										
D	2006	(DC)STS-V8	Body	Uplevel Radio																																																										
D	2006	(DC)STS-V8	Body	Navigation Radio																																																										
D	2006	(DC)STS-V8	Body	Rear Integration Module																																																										
D	2006	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																										
D	2006	(DC)STS-V8	Body	Right Rear Door Module																																																										
D	2006	(DC)STS-V8	Body	Steering Column Lock Module																																																										
D	2006	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																										
D	2006	(DC)STS-V8	Body	TV Antenna Module																																																										
D	2006	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																										
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2006	(DW)STS	Chassis	Electronic Brake Control Module																																																										
D	2006	(DW)STS	Chassis	Electronic Suspension Control																																																										
D	2006	(DW)STS	Body	Amplifier (Bose)																																																										
D	2006	(DW)STS	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2006	(DW)STS	Body	Distance Sensing Cruise Control																																																										
D	2006	(DW)STS	Body	Driver Door Module																																																										
D	2006	(DW)STS	Body	Driver Door Switch																																																										
D	2006	(DW)STS	Body	Driver Position Module																																																										
D	2006	(DW)STS	Body	Headlamp Control Module																																																										
D	2006	(DW)STS	Body	Head Up Display																																																										
D	2006	(DW)STS	Body	HVAC Control Module																																																										
D	2006	(DW)STS	Body	Instrument Panel Cluster																																																										
D	2006	(DW)STS	Body	Instrument Panel Module																																																										
D	2006	(DW)STS	Body	Left Rear Door Module																																																										
D	2006	(DW)STS	Body	Passenger Door Module																																																										
D	2006	(DW)STS	Body	Uplevel Radio																																																										
D	2006	(DW)STS	Body	Navigation Radio																																																										
D	2006	(DW)STS	Body	Rear Integration Module																																																										
D	2006	(DW)STS	Body	Remote Control Door Lock Receiver																																																										
D	2006	(DW)STS	Body	Right Rear Door Module																																																										
D	2006	(DW)STS	Body	Steering Column Lock Module																																																										
D	2006	(DW)STS	Body	Supplemental Inflatable Restraint																																																										
D	2006	(DW)STS	Body	TV Antenna Module																																																										
D	2006	(DW)STS	Body	Vehicle Comm. Interface Module																																																										
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
D	2006	(DX)STS-V	Chassis	Electronic Brake Control Module																																																										
D	2006	(DX)STS-V	Chassis	Electronic Suspension Control																																																										
D	2006	(DX)STS-V	Body	Amplifier (Bose)																																																										
D	2006	(DX)STS-V	Body	Digital Radio Receiver																																																										
D	2006	(DX)STS-V	Body	Distance Sensing Cruise Control																																																										
D	2006	(DX)STS-V	Body	Driver Door Module																																																										
D	2006	(DX)STS-V	Body	Driver Door Switch																																																										
D	2006	(DX)STS-V	Body	Driver Position Module																																																										
D	2006	(DX)STS-V	Body	Headlamp Control Module																																																										
D	2006	(DX)STS-V	Body	Head Up Display																																																										
D	2006	(DX)STS-V	Body	HVAC Control Module																																																										
D	2006	(DX)STS-V	Body	Instrument Panel Cluster																																																										
D	2006	(DX)STS-V	Body	Instrument Panel Module																																																										
D	2006	(DX)STS-V	Body	Left Rear Door Module																																																										
D	2006	(DX)STS-V	Body	Passenger Door Module																																																										
D	2006	(DX)STS-V	Body	Uplevel Radio																																																										
D	2006	(DX)STS-V	Body	Navigation Radio																																																										
D	2006	(DX)STS-V	Body	Rear Integration Module																																																										
D	2006	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																										
D	2006	(DX)STS-V	Body	Right Rear Door Module																																																										
D	2006	(DX)STS-V	Body	Steering Column Lock Module																																																										
D	2006	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																										
D	2006	(DX)STS-V	Body	TV Antenna Module																																																										
D	2006	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																										
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																										
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																										
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																										
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2007	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2007	(DM)CTS	Chassis	VES																																																										
D	2007	(DM)CTS	Body	Amplifier (Bose)																																																										
D	2007	(DM)CTS	Body	Amplifier (Delco)																																																										
D	2007	(DM)CTS	Body	Climate Control Panel																																																										
D	2007	(DM)CTS	Body	Dash Integration Module																																																										
D	2007	(DM)CTS	Body	Digital Radio Receiver																																																										
D	2007	(DM)CTS	Body	Driver Door Switch																																																										
D	2007	(DM)CTS	Body	Driver Door Module																																																										
D	2007	(DM)CTS	Body	Passenger Door Module																																																										
D	2007	(DM)CTS	Body	Left Rear Door Module																																																										
D	2007	(DM)CTS	Body	Right Rear Door Module																																																										
D	2007	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2007	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2007	(DM)CTS	Body	Instrument Panel Cluster																																																										
D	2007	(DM)CTS	Body	Memory Seat Module																																																										
D	2007	(DM)CTS	Body	Personalization																																																										
D	2007	(DM)CTS	Body	Rear Integration Module																																																										
D	2007	(DM)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2007	(DM)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DM)CTS	Body	Theft Deterrent Module																																																										
D	2007	(DM)CTS	Body	TV Antenna Module																																																										
D	2007	(DM)CTS	Body	Vehicle Comm. Interface Module																																																										
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																										
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																										
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																										
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																										
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2007	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2007	(DP)CTS	Chassis	VES																																																										
D	2007	(DP)CTS	Body	Amplifier (Bose)																																																										
D	2007	(DP)CTS	Body	Amplifier (Delco)																																																										
D	2007	(DP)CTS	Body	Climate Control Panel																																																										
D	2007	(DP)CTS	Body	Dash Integration Module																																																										
D	2007	(DP)CTS	Body	Digital Radio Receiver																																																										
D	2007	(DP)CTS	Body	Driver Door Switch																																																										
D	2007	(DP)CTS	Body	Driver Door Module																																																										
D	2007	(DP)CTS	Body	Passenger Door Module																																																										
D	2007	(DP)CTS	Body	Left Rear Door Module																																																										
D	2007	(DP)CTS	Body	Right Rear Door Module																																																										
D	2007	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2007	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2007	(DP)CTS	Body	Instrument Panel Cluster																																																										
D	2007	(DP)CTS	Body	Memory Seat Module																																																										
D	2007	(DP)CTS	Body	Personalization																																																										
D	2007	(DP)CTS	Body	Rear Integration Module																																																										
D	2007	(DP)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2007	(DP)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DP)CTS	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2007	(DP)CTS	Body	TV Antenna Module																																																											
D	2007	(DP)CTS	Body	Vehicle Comm. Interface Module																																																											
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																											
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																											
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																											
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																											
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2007	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2007	(DR)CTS	Chassis	VES																																																											
D	2007	(DR)CTS	Body	Amplifier (Bose)																																																											
D	2007	(DR)CTS	Body	Amplifier (Delco)																																																											
D	2007	(DR)CTS	Body	Climate Control Panel																																																											
D	2007	(DR)CTS	Body	Dash Integration Module																																																											
D	2007	(DR)CTS	Body	Digital Radio Receiver																																																											
D	2007	(DR)CTS	Body	Driver Door Switch																																																											
D	2007	(DR)CTS	Body	Driver Door Module																																																											
D	2007	(DR)CTS	Body	Passenger Door Module																																																											
D	2007	(DR)CTS	Body	Left Rear Door Module																																																											
D	2007	(DR)CTS	Body	Right Rear Door Module																																																											
D	2007	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2007	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2007	(DR)CTS	Body	Instrument Panel Cluster																																																											
D	2007	(DR)CTS	Body	Memory Seat Module																																																											
D	2007	(DR)CTS	Body	Personalization																																																											
D	2007	(DR)CTS	Body	Rear Integration Module																																																											
D	2007	(DR)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2007	(DR)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2007	(DR)CTS	Body	Theft Deterrent Module																																																											
D	2007	(DR)CTS	Body	TV Antenna Module																																																											
D	2007	(DR)CTS	Body	Vehicle Comm. Interface Module																																																											
D	2007	(DN)CTS-V	Powertrain	(U)6.0L V8 LS2 Engine Control Module																																																											
D	2007	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																											
D	2007	(DN)CTS-V	Chassis	VES																																																											
D	2007	(DN)CTS-V	Body	Amplifier (Bose)																																																											
D	2007	(DN)CTS-V	Body	Amplifier (Delco)																																																											
D	2007	(DN)CTS-V	Body	Climate Control Panel																																																											
D	2007	(DN)CTS-V	Body	Dash Integration Module																																																											
D	2007	(DN)CTS-V	Body	Digital Radio Receiver																																																											
D	2007	(DN)CTS-V	Body	Driver Door Switch																																																											
D	2007	(DN)CTS-V	Body	Driver Door Module																																																											
D	2007	(DN)CTS-V	Body	Passenger Door Module																																																											
D	2007	(DN)CTS-V	Body	Left Rear Door Module																																																											
D	2007	(DN)CTS-V	Body	Right Rear Door Module																																																											
D	2007	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																											
D	2007	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																											
D	2007	(DN)CTS-V	Body	Instrument Panel Cluster																																																											
D	2007	(DN)CTS-V	Body	Memory Seat Module																																																											
D	2007	(DN)CTS-V	Body	Personalization																																																											
D	2007	(DN)CTS-V	Body	Rear Integration Module																																																											
D	2007	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2007	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DN)CTS-V	Body	Theft Deterrent Module																																																										
D	2007	(DN)CTS-V	Body	TV Antenna Module																																																										
D	2007	(DN)CTS-V	Body	Vehicle Comm. Interface Module																																																										
D	2007	(DC)STS-V8	Powertrain	Engine Control Module																																																										
D	2007	(DC)STS-V8	Powertrain	Transmission Control Module																																																										
D	2007	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																										
D	2007	(DC)STS-V8	Chassis	Electronic Suspension Control																																																										
D	2007	(DC)STS-V8	Body	Amplifier (Bose)																																																										
D	2007	(DC)STS-V8	Body	Digital Radio Receiver																																																										
D	2007	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																										
D	2007	(DC)STS-V8	Body	Driver Door Module																																																										
D	2007	(DC)STS-V8	Body	Driver Door Switch																																																										
D	2007	(DC)STS-V8	Body	Driver Position Module																																																										
D	2007	(DC)STS-V8	Body	Headlamp Control Module																																																										
D	2007	(DC)STS-V8	Body	Head Up Display																																																										
D	2007	(DC)STS-V8	Body	HVAC Control Module																																																										
D	2007	(DC)STS-V8	Body	Instrument Panel Cluster																																																										
D	2007	(DC)STS-V8	Body	Instrument Panel Module																																																										
D	2007	(DC)STS-V8	Body	Left Rear Door Module																																																										
D	2007	(DC)STS-V8	Body	Passenger Door Module																																																										
D	2007	(DC)STS-V8	Body	Uplevel Radio																																																										
D	2007	(DC)STS-V8	Body	Navigation Radio																																																										
D	2007	(DC)STS-V8	Body	Rear Integration Module																																																										
D	2007	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																										
D	2007	(DC)STS-V8	Body	Right Rear Door Module																																																										
D	2007	(DC)STS-V8	Body	Steering Column Lock Module																																																										
D	2007	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DC)STS-V8	Body	TV Antenna Module																																																										
D	2007	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																										
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2007	(DW)STS	Chassis	Electronic Brake Control Module																																																										
D	2007	(DW)STS	Chassis	Electronic Suspension Control																																																										
D	2007	(DW)STS	Body	Amplifier (Bose)																																																										
D	2007	(DW)STS	Body	Digital Radio Receiver																																																										
D	2007	(DW)STS	Body	Distance Sensing Cruise Control																																																										
D	2007	(DW)STS	Body	Driver Door Module																																																										
D	2007	(DW)STS	Body	Driver Door Switch																																																										
D	2007	(DW)STS	Body	Driver Position Module																																																										
D	2007	(DW)STS	Body	Headlamp Control Module																																																										
D	2007	(DW)STS	Body	Head Up Display																																																										
D	2007	(DW)STS	Body	HVAC Control Module																																																										
D	2007	(DW)STS	Body	Instrument Panel Cluster																																																										
D	2007	(DW)STS	Body	Instrument Panel Module																																																										
D	2007	(DW)STS	Body	Left Rear Door Module																																																										
D	2007	(DW)STS	Body	Passenger Door Module																																																										
D	2007	(DW)STS	Body	Uplevel Radio																																																										
D	2007	(DW)STS	Body	Navigation Radio																																																										
D	2007	(DW)STS	Body	Rear Integration Module																																																										
D	2007	(DW)STS	Body	Remote Control Door Lock Receiver																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2007	(DW)STS	Body	Right Rear Door Module																																																											
D	2007	(DW)STS	Body	Steering Column Lock Module																																																											
D	2007	(DW)STS	Body	Supplemental Inflatable Restraint																																																											
D	2007	(DW)STS	Body	TV Antenna Module																																																											
D	2007	(DW)STS	Body	Vehicle Comm. Interface Module																																																											
D	2007	(DX)STS-V	Powertrain	Engine Control Module																																																											
D	2007	(DX)STS-V	Powertrain	Transmission Control Module																																																											
D	2007	(DX)STS-V	Chassis	Electronic Brake Control Module																																																											
D	2007	(DX)STS-V	Chassis	Electronic Suspension Control																																																											
D	2007	(DX)STS-V	Body	Amplifier (Bose)																																																											
D	2007	(DX)STS-V	Body	Digital Radio Receiver																																																											
D	2007	(DX)STS-V	Body	Distance Sensing Cruise Control																																																											
D	2007	(DX)STS-V	Body	Driver Door Module																																																											
D	2007	(DX)STS-V	Body	Driver Door Switch																																																											
D	2007	(DX)STS-V	Body	Driver Position Module																																																											
D	2007	(DX)STS-V	Body	Headlamp Control Module																																																											
D	2007	(DX)STS-V	Body	Head Up Display																																																											
D	2007	(DX)STS-V	Body	HVAC Control Module																																																											
D	2007	(DX)STS-V	Body	Instrument Panel Cluster																																																											
D	2007	(DX)STS-V	Body	Instrument Panel Module																																																											
D	2007	(DX)STS-V	Body	Left Rear Door Module																																																											
D	2007	(DX)STS-V	Body	Passenger Door Module																																																											
D	2007	(DX)STS-V	Body	Uplevel Radio																																																											
D	2007	(DX)STS-V	Body	Navigation Radio																																																											
D	2007	(DX)STS-V	Body	Rear Integration Module																																																											
D	2007	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																											
D	2007	(DX)STS-V	Body	Right Rear Door Module																																																											
D	2007	(DX)STS-V	Body	Steering Column Lock Module																																																											
D	2007	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																											
D	2007	(DX)STS-V	Body	TV Antenna Module																																																											
D	2007	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																											
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																											
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																											
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																											
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																											
D	2008	CTS	Chassis	Electronic Brake Control Module																																																											
D	2008	CTS	Body	Body Control Module																																																											
D	2008	CTS	Body	Body Control Module (aux.)																																																											
D	2008	CTS	Body	Driver Door Switch																																																											
D	2008	CTS	Body	Headlamp Control Module																																																											
D	2008	CTS	Body	HVAC Control Module																																																											
D	2008	CTS	Body	Infotainment Faceplate Module																																																											
D	2008	CTS	Body	Instrument Panel Cluster																																																											
D	2008	CTS	Body	Memory Seat Module																																																											
D	2008	CTS	Body	Park Assist Module																																																											
D	2008	CTS	Body	Passenger Door Switch																																																											
D	2008	CTS	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2008	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2008	CTS	Body	Radio																																																										
D	2008	CTS	Body	Supplemental Inflatable Restraint																																																										
D	2008	CTS	Body	TV Antenna Module																																																										
D	2008	CTS	Body	Vehicle Comm. Interface Module																																																										
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2008	SLS	Chassis	Electronic Brake Control Module																																																										
D	2008	SLS	Chassis	Electronic Suspension Control																																																										
D	2008	SLS	Body	Amplifier (Bose)																																																										
D	2008	SLS	Body	Driver Door Module																																																										
D	2008	SLS	Body	Driver Door Switch																																																										
D	2008	SLS	Body	Driver Position Module																																																										
D	2008	SLS	Body	Headlamp Control Module																																																										
D	2008	SLS	Body	HVAC Control Module																																																										
D	2008	SLS	Body	Instrument Panel Cluster																																																										
D	2008	SLS	Body	Instrument Panel Module																																																										
D	2008	SLS	Body	Left Rear Door Module																																																										
D	2008	SLS	Body	Passenger Door Module																																																										
D	2008	SLS	Body	Radio																																																										
D	2008	SLS	Body	Rear HVAC/RSA																																																										
D	2008	SLS	Body	Rear Integration Module																																																										
D	2008	SLS	Body	Remote Control Door Lock Receiver																																																										
D	2008	SLS	Body	Right Rear Door Module																																																										
D	2008	SLS	Body	Supplemental Inflatable Restraint																																																										
D	2008	SLS	Body	TV Antenna Module																																																										
D	2008	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																										
D	2008	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2008	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																										
D	2008	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																										
D	2008	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																										
D	2008	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																										
D	2008	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																										
D	2008	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																										
D	2008	STS	Body	Amplifier (Bose)																																																										
D	2008	STS	Body	Digital Radio Receiver																																																										
D	2008	STS	Body	Distance Sensing Cruise Control																																																										
D	2008	STS	Body	Driver Door Module																																																										
D	2008	STS	Body	Driver Door Switch																																																										
D	2008	STS	Body	Driver Position Module																																																										
D	2008	STS	Body	Headlamp Control Module																																																										
D	2008	STS	Body	Head Up Display																																																										
D	2008	STS	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2008	STS	Body	Instrument Panel Cluster																																																										
D	2008	STS	Body	Instrument Panel Module																																																										
D	2008	STS	Body	Left Rear Door Module																																																										
D	2008	STS	Body	Left Side Object Detection Module																																																										
D	2008	STS	Body	Passenger Door Module																																																										
D	2008	STS	Body	Uplevel Radio																																																										
D	2008	STS	Body	Navigation Radio																																																										
D	2008	STS	Body	Rear Integration Module																																																										
D	2008	STS	Body	Remote Control Door Lock Receiver																																																										
D	2008	STS	Body	Right Rear Door Module																																																										
D	2008	STS	Body	Right Side Object Detection Module																																																										
D	2008	STS	Body	Steering Column Lock Module																																																										
D	2008	STS	Body	Supplemental Inflatable Restraint																																																										
D	2008	STS	Body	TV Antenna Module																																																										
D	2008	STS	Body	Vehicle Comm. Interface Module																																																										
D	2008	STS	Body	Veh Direction Alert Alarm Warn Mod																																																										
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																										
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																										
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																										
D	2009	CTS	Chassis	Electronic Brake Control Module																																																										
D	2009	CTS	Chassis	Electronic Suspension Control																																																										
D	2009	CTS	Chassis	Parking Brake Control Module																																																										
D	2009	CTS	Body	Body Control Module																																																										
D	2009	CTS	Body	Body Control Module (aux.)																																																										
D	2009	CTS	Body	Driver Door Switch																																																										
D	2009	CTS	Body	Headlamp Control Module																																																										
D	2009	CTS	Body	HVAC Control Module																																																										
D	2009	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																										
D	2009	CTS	Body	Instrument Panel Cluster (Other)																																																										
D	2009	CTS	Body	Memory Seat Module																																																										
D	2009	CTS	Body	Park Assist Module																																																										
D	2009	CTS	Body	Passenger Door Switch																																																										
D	2009	CTS	Body	Passenger Presence System																																																										
D	2009	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2009	CTS	Body	Radio																																																										
D	2009	CTS	Body	Supplemental Inflatable Restraint																																																										
D	2009	CTS	Body	TV Antenna Module																																																										
D	2009	CTS	Body	Vehicle Comm. Interface Module																																																										
D	2009	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2009	SLS	Powertrain	(T)2.8L V6 LP2 Transmission Control Module																																																										
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																											
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
D	2009	SLS	Chassis	Electronic Brake Control Module																																																											
D	2009	SLS	Chassis	Electronic Suspension Control																																																											
D	2009	SLS	Body	Amplifier (Bose)																																																											
D	2009	SLS	Body	Driver Door Module																																																											
D	2009	SLS	Body	Driver Door Switch																																																											
D	2009	SLS	Body	Driver Position Module																																																											
D	2009	SLS	Body	Headlamp Control Module																																																											
D	2009	SLS	Body	HVAC Control Module																																																											
D	2009	SLS	Body	Instrument Panel Cluster																																																											
D	2009	SLS	Body	Instrument Panel Module																																																											
D	2009	SLS	Body	Left Rear Door Module																																																											
D	2009	SLS	Body	Passenger Door Module																																																											
D	2009	SLS	Body	Radio																																																											
D	2009	SLS	Body	Rear HVAC/RSA																																																											
D	2009	SLS	Body	Rear Integration Module																																																											
D	2009	SLS	Body	Remote Control Door Lock Receiver																																																											
D	2009	SLS	Body	Right Rear Door Module																																																											
D	2009	SLS	Body	Supplemental Inflatable Restraint																																																											
D	2009	SLS	Body	TV Antenna Module																																																											
D	2009	SLS	Body	Vehicle Comm. Interface Module																																																											
D	2009	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																											
D	2009	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																											
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																											
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																											
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																											
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
D	2009	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																											
D	2009	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																											
D	2009	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																											
D	2009	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																											
D	2009	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																											
D	2009	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																											
D	2009	STS	Body	Amplifier (Bose)																																																											
D	2009	STS	Body	Digital Radio Receiver																																																											
D	2009	STS	Body	Distance Sensing Cruise Control																																																											
D	2009	STS	Body	Driver Door Module																																																											
D	2009	STS	Body	Driver Door Switch																																																											
D	2009	STS	Body	Driver Position Module																																																											
D	2009	STS	Body	Headlamp Control Module																																																											
D	2009	STS	Body	Head Up Display																																																											
D	2009	STS	Body	HVAC Control Module																																																											
D	2009	STS	Body	Instrument Panel Cluster																																																											
D	2009	STS	Body	Instrument Panel Module																																																											
D	2009	STS	Body	Left Rear Door Module																																																											
D	2009	STS	Body	Left Side Object Detection Module																																																											
D	2009	STS	Body	Passenger Door Module																																																											
D	2009	STS	Body	Uplevel Radio																																																											
D	2009	STS	Body	Navigation Radio																																																											
D	2009	STS	Body	Rear Integration Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2009	STS	Body	Remote Control Door Lock Receiver																																																										
D	2009	STS	Body	Right Rear Door Module																																																										
D	2009	STS	Body	Right Side Object Detection Module																																																										
D	2009	STS	Body	Steering Column Lock Module																																																										
D	2009	STS	Body	Supplemental Inflatable Restraint																																																										
D	2009	STS	Body	TV Antenna Module																																																										
D	2009	STS	Body	Vehicle Comm. Interface Module																																																										
D	2009	STS	Body	Veh Direction Alert Alarm Warn Mod																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Auto																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Manual																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transmission Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transfer Case Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module Auto																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																										
D	2010	CTS	Chassis	Electronic Brake Control Module																																																										
D	2010	CTS	Chassis	Electronic Suspension Control																																																										
D	2010	CTS	Chassis	Parking Brake Control Module																																																										
D	2010	CTS	Body	Body Control Module																																																										
D	2010	CTS	Body	Body Control Module (aux.)																																																										
D	2010	CTS	Body	Driver Door Switch																																																										
D	2010	CTS	Body	Headlamp Control Module																																																										
D	2010	CTS	Body	HVAC Control Module																																																										
D	2010	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																										
D	2010	CTS	Body	Instrument Panel Cluster (Other)																																																										
D	2010	CTS	Body	Liftgate Module																																																										
D	2010	CTS	Body	Memory Seat Module																																																										
D	2010	CTS	Body	Park Assist Module																																																										
D	2010	CTS	Body	Passenger Door Switch																																																										
D	2010	CTS	Body	Passenger Presence System																																																										
D	2010	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2010	CTS	Body	Radio																																																										
D	2010	CTS	Body	Supplemental Inflatable Restraint																																																										
D	2010	CTS	Body	TV Antenna Module																																																										
D	2010	CTS	Body	Vehicle Comm. Interface Module																																																										
D	2010	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																										
D	2010	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2010	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																										
D	2010	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2010	STS	Body	Amplifier (Bose)																																																										
D	2010	STS	Body	Digital Radio Receiver																																																										
D	2010	STS	Body	Distance Sensing Cruise Control																																																										
D	2010	STS	Body	Driver Door Module																																																										
D	2010	STS	Body	Driver Door Switch																																																										
D	2010	STS	Body	Driver Position Module																																																										
D	2010	STS	Body	Headlamp Control Module																																																										
D	2010	STS	Body	Head Up Display																																																										
D	2010	STS	Body	HVAC Control Module																																																										
D	2010	STS	Body	Instrument Panel Cluster																																																										
D	2010	STS	Body	Instrument Panel Module																																																										
D	2010	STS	Body	Left Rear Door Module																																																										
D	2010	STS	Body	Left Side Object Detection Module																																																										
D	2010	STS	Body	Passenger Door Module																																																										
D	2010	STS	Body	Uplevel Radio																																																										
D	2010	STS	Body	Navigation Radio																																																										
D	2010	STS	Body	Rear Integration Module																																																										
D	2010	STS	Body	Remote Control Door Lock Receiver																																																											
D	2010	STS	Body	Right Rear Door Module																																																										
D	2010	STS	Body	Right Side Object Detection Module																																																										
D	2010	STS	Body	Steering Column Lock Module																																																										
D	2010	STS	Body	Supplemental Inflatable Restraint																																																										
D	2010	STS	Body	TV Antenna Module																																																										
D	2010	STS	Body	Vehicle Comm. Interface Module																																																										
D	2010	STS	Body	Veh Direction Alert Alarm Warn Mod																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Auto																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Manual																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transfer Case Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Fuel Pump Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transfer Case Control Module																																																										
D	2011	CTS	Chassis	Electronic Brake Control Module																																																										
D	2011	CTS	Chassis	Electronic Suspension Control																																																										
D	2011	CTS	Chassis	Parking Brake Control Module																																																										
D	2011	CTS	Body	Body Control Module (6.2L V8 LSA)																																																										
D	2011	CTS	Body	Body Control Module (Other)																																																										
D	2011	CTS	Body	Body Control Module (aux.)																																																										
D	2011	CTS	Body	Driver Door Switch																																																										
D	2011	CTS	Body	Headlamp Control Module																																																										
D	2011	CTS	Body	HVAC Control Module																																																										
D	2011	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																										
D	2011	CTS	Body	Instrument Panel Cluster (Other)																																																										
D	2011	CTS	Body	Liftgate Module																																																										
D	2011	CTS	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2011	CTS	Body	Park Assist Module																																																										
D	2011	CTS	Body	Passenger Door Switch																																																										
D	2011	CTS	Body	Passenger Presence System																																																										
D	2011	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2011	CTS	Body	Radio																																																										
D	2011	CTS	Body	Supplemental Inflatable Restraint																																																										
D	2011	CTS	Body	TV Antenna Module																																																										
D	2011	CTS	Body	Vehicle Comm. Interface Module																																																										
D	2011	STS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																										
D	2011	STS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																										
D	2011	STS	Chassis	Electronic Brake Control Module																																																										
D	2011	STS	Chassis	Electronic Suspension Control																																																										
D	2011	STS	Body	Amplifier (Bose)																																																										
D	2011	STS	Body	Digital Radio Receiver																																																										
D	2011	STS	Body	Distance Sensing Cruise Control																																																										
D	2011	STS	Body	Driver Door Module																																																										
D	2011	STS	Body	Driver Door Switch																																																										
D	2011	STS	Body	Driver Position Module																																																										
D	2011	STS	Body	Headlamp Control Module																																																										
D	2011	STS	Body	Head Up Display																																																										
D	2011	STS	Body	HVAC Control Module																																																										
D	2011	STS	Body	Instrument Panel Cluster																																																										
D	2011	STS	Body	Instrument Panel Module																																																										
D	2011	STS	Body	Left Rear Door Module																																																										
D	2011	STS	Body	Left Side Object Detection Module																																																										
D	2011	STS	Body	Passenger Door Module																																																										
D	2011	STS	Body	Uplevel Radio																																																										
D	2011	STS	Body	Navigation Radio																																																										
D	2011	STS	Body	Rear Integration Module																																																										
D	2011	STS	Body	Remote Control Door Lock Receiver																																																										
D	2011	STS	Body	Right Rear Door Module																																																										
D	2011	STS	Body	Right Side Object Detection Module																																																										
D	2011	STS	Body	Supplemental Inflatable Restraint																																																										
D	2011	STS	Body	TV Antenna Module																																																										
D	2011	STS	Body	Vehicle Comm. Interface Module																																																										
D	2011	STS	Body	Veh Direction Alert Alarm Warn Mod																																																										
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2012	P Type Engine	Chassis	Electronic Brake Control Module																																																										
D	2012	P Type Engine	Chassis	Electronic Suspension Control																																																										
D	2012	P Type Engine	Chassis	Parking Brake Control Module																																																										
D	2012	P Type Engine	Body	Body Control Module																																																										
D	2012	P Type Engine	Body	Body Control Module (aux.)																																																										
D	2012	P Type Engine	Body	Driver Door Switch																																																										
D	2012	P Type Engine	Body	Headlamp Control Module																																																										
D	2012	P Type Engine	Body	HVAC Control Module																																																										
D	2012	P Type Engine	Body	Instrument Panel Cluster																																																										
D	2012	P Type Engine	Body	Left Side Object Detection Module																																																										
D	2012	P Type Engine	Body	Liftgate Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2012	P Type Engine	Body	Memory Seat Module																																																										
D	2012	P Type Engine	Body	Park Assist Module																																																										
D	2012	P Type Engine	Body	Passenger Door Switch																																																										
D	2012	P Type Engine	Body	Passenger Presence System																																																										
D	2012	P Type Engine	Body	Pedestrian Impact Detection Module																																																										
D	2012	P Type Engine	Body	Radio																																																										
D	2012	P Type Engine	Body	Right Side Object Detection Module																																																										
D	2012	P Type Engine	Body	Supplemental Inflatable Restraint																																																										
D	2012	P Type Engine	Body	TV Antenna Module																																																										
D	2012	P Type Engine	Body	Vehicle Comm. Interface Module																																																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto																																																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual																																																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																										
D	2012	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
D	2012	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																										
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																										
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																										
D	2012	Other	Chassis	Electronic Brake Control Module																																																										
D	2012	Other	Chassis	Electronic Suspension Control																																																										
D	2012	Other	Chassis	Parking Brake Control Module																																																										
D	2012	Other	Body	Body Control Module																																																										
D	2012	Other	Body	Body Control Module (aux.)																																																										
D	2012	Other	Body	Driver Door Switch																																																										
D	2012	Other	Body	Headlamp Control Module																																																										
D	2012	Other	Body	HVAC Control Module																																																										
D	2012	Other	Body	Instrument Panel Cluster																																																										
D	2012	Other	Body	Left Side Object Detection Module																																																										
D	2012	Other	Body	Liftgate Module																																																										
D	2012	Other	Body	Memory Seat Module																																																										
D	2012	Other	Body	Park Assist Module																																																										
D	2012	Other	Body	Passenger Door Switch																																																										
D	2012	Other	Body	Passenger Presence System																																																										
D	2012	Other	Body	Pedestrian Impact Detection Module																																																										
D	2012	Other	Body	Radio																																																										
D	2012	Other	Body	Right Side Object Detection Module																																																										
D	2012	Other	Body	Supplemental Inflatable Restraint																																																										
D	2012	Other	Body	TV Antenna Module																																																										
D	2012	Other	Body	Vehicle Comm. Interface Module																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2013	P Type Engine	Chassis	Electronic Brake Control Module																																																										
D	2013	P Type Engine	Chassis	Electronic Suspension Control																																																										
D	2013	P Type Engine	Chassis	Parking Brake Control Module																																																										
D	2013	P Type Engine	Body	Body Control Module																																																										
D	2013	P Type Engine	Body	Body Control Module (aux.)																																																										
D	2013	P Type Engine	Body	Driver Door Switch																																																										
D	2013	P Type Engine	Body	Headlamp Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2013	P Type Engine	Body	HVAC Control Module																																																										
D	2013	P Type Engine	Body	Instrument Panel Cluster																																																										
D	2013	P Type Engine	Body	Left Side Object Detection Module																																																										
D	2013	P Type Engine	Body	Liftgate Module																																																										
D	2013	P Type Engine	Body	Memory Seat Module																																																										
D	2013	P Type Engine	Body	Park Assist Module																																																										
D	2013	P Type Engine	Body	Passenger Door Switch																																																										
D	2013	P Type Engine	Body	Passenger Presence System																																																										
D	2013	P Type Engine	Body	Pedestrian Impact Detection Module																																																										
D	2013	P Type Engine	Body	Radio																																																										
D	2013	P Type Engine	Body	Right Side Object Detection Module																																																										
D	2013	P Type Engine	Body	Supplemental Inflatable Restraint																																																										
D	2013	P Type Engine	Body	TV Antenna Module																																																										
D	2013	P Type Engine	Body	Vehicle Comm. Interface Module																																																										
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto																																																										
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual																																																										
D	2013	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																										
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																										
D	2013	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
D	2013	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																										
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																										
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																										
D	2013	Other	Chassis	Electronic Brake Control Module																																																										
D	2013	Other	Chassis	Electronic Suspension Control																																																										
D	2013	Other	Chassis	Parking Brake Control Module																																																										
D	2013	Other	Body	Body Control Module																																																										
D	2013	Other	Body	Body Control Module (aux.)																																																										
D	2013	Other	Body	Driver Door Switch																																																										
D	2013	Other	Body	Headlamp Control Module																																																										
D	2013	Other	Body	HVAC Control Module																																																										
D	2013	Other	Body	Instrument Panel Cluster																																																										
D	2013	Other	Body	Left Side Object Detection Module																																																										
D	2013	Other	Body	Liftgate Module																																																										
D	2013	Other	Body	Memory Seat Module																																																										
D	2013	Other	Body	Park Assist Module																																																										
D	2013	Other	Body	Passenger Door Switch																																																										
D	2013	Other	Body	Passenger Presence System																																																										
D	2013	Other	Body	Pedestrian Impact Detection Module																																																										
D	2013	Other	Body	Radio																																																										
D	2013	Other	Body	Right Side Object Detection Module																																																										
D	2013	Other	Body	Supplemental Inflatable Restraint																																																										
D	2013	Other	Body	TV Antenna Module																																																										
D	2013	Other	Body	Vehicle Comm. Interface Module																																																										
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
D	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
D	2014	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																										
D	2014	CTS	Powertrain	Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2014	CTS	Powertrain	Transfer Case Control Module																																																										
D	2014	CTS	Chassis	Electronic Brake Control Module																																																											
D	2014	CTS	Chassis	Parking Brake Control Module																																																											
D	2014	CTS	Chassis	Suspension Control Module																																																											
D	2014	CTS	Body	Body Control Module Coupe																																																											
D	2014	CTS	Body	Body Control Module Station Wagon																																																											
D	2014	CTS	Body	Auxiliary Body Control Module																																																											
D	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	CTS	Body	Passenger Presence Module																																																											
D	2014	CTS	Body	Pedestrian Impact Detection Module																																																											
D	2014	CTS	Body	Instrument Cluster																																																											
D	2014	CTS	Body	Headlamp Control Module																																																											
D	2014	CTS	Body	Radio																																																											
D	2014	CTS	Body	Amplifier																																																											
D	2014	CTS	Body	Television Antenna Module																																																											
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	CTS	Body	HVAC Control Module																																																											
D	2014	CTS	Body	Driver Door Switch Panel Control Module																																																											
D	2014	CTS	Body	Passenger Door Switch Panel Control Module																																																											
D	2014	CTS	Body	Liftgate Control Module																																																											
D	2014	CTS	Body	Seat Memory Control Module	V	V	V																																																								
D	2014	CTS	Body	Right Side Object Detection Control Module																																																											
D	2014	CTS	Body	Left Side Object Detection Control Module																																																											
D	2014	CTS	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)				V	V	V	V	V	V																																																		
D	2014	CTS	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
D	2014	CTS	Body	Parking Assist Control Module																																																											
D	2014	CTS	Body	Theft Deterrent Module				V	V																																																						
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
D	2015	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																											
D	2015	CTS	Powertrain	Chassis Control Module																																																											
D	2015	CTS	Powertrain	Transfer Case Control Module																																																											
D	2015	CTS	Chassis	Electronic Brake Control Module																																																											
D	2015	CTS	Chassis	Parking Brake Control Module																																																											
D	2015	CTS	Chassis	Suspension Control Module																																																											
D	2015	CTS	Body	Body Control Module Coupe																																																											
D	2015	CTS	Body	Body Control Module Station Wagon																																																											
D	2015	CTS	Body	Auxiliary Body Control Module																																																											
D	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	CTS	Body	Passenger Presence Module																																																											
D	2015	CTS	Body	Pedestrian Impact Detection Module																																																											
D	2015	CTS	Body	Instrument Cluster																																																											
D	2015	CTS	Body	Headlamp Control Module																																																											
D	2015	CTS	Body	Radio																																																											
D	2015	CTS	Body	Amplifier																																																											
D	2015	CTS	Body	Television Antenna Module																																																											
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2015	CTS	Body	HVAC Control Module																																																											
D	2015	CTS	Body	Driver Door Switch Panel Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2015	CTS	Body	Passenger Door Switch Panel Control Module																																																											
D	2015	CTS	Body	Liftgate Control Module																																																											
D	2015	CTS	Body	Seat Memory Control Module	V	V	V																																																							
D	2015	CTS	Body	Right Side Object Detection Control Module																																																										
D	2015	CTS	Body	Left Side Object Detection Control Module																																																										
D	2015	CTS	Body	Remote Control Door Lock Receiver				V	V	V	V	V	V																																																	
D	2015	CTS	Body	Parking Assist Control Module																																																										
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module										V																																																
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module											V																																															
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module										V																																																
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module											V																																															
K	2004	(KD)Deville	Body	Amplifier (Delco)												V	V																																													
K	2004	(KD)Deville	Body	CD Changer																																																											
K	2004	(KD)Deville	Body	Dash Integration Module												V	V	V																																												
K	2004	(KD)Deville	Body	Digital Radio Receiver																																																											
K	2004	(KD)Deville	Body	Driver Door Switch																																																											
K	2004	(KD)Deville	Body	Driver Door Module																																																											
K	2004	(KD)Deville	Body	Passenger Door Module																																																											
K	2004	(KD)Deville	Body	Left Rear Door Module																																																											
K	2004	(KD)Deville	Body	Right Rear Door Module																																																											
K	2004	(KD)Deville	Body	Instrument Panel Cluster																																																											
K	2004	(KD)Deville	Body	Instrument Panel Module															V																																											
K	2004	(KD)Deville	Body	Memory Seat Module																																																											
K	2004	(KD)Deville	Body	Navigation Radio																V																																										
K	2004	(KD)Deville	Body	Radio																	V	V	V	V																																					
K	2004	(KD)Deville	Body	Rear Climate Control Panel																																																											
K	2004	(KD)Deville	Body	Rear Integration Module												V	V								V																																					
K	2004	(KD)Deville	Body	Remote Function Actuation																																																											
K	2004	(KD)Deville	Body	Supplemental Inflatable Restraint																																																											
K	2004	(KD)Deville	Body	Tilt Telescope Module																																																											
K	2004	(KD)Deville	Body	Vehicle Theft Deterrent																																																											
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module										V																																																
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module											V																																															
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module										V																																																
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module											V																																															
K	2004	(KE)DHS	Body	Amplifier (Bose)																																																											
K	2004	(KE)DHS	Body	CD Changer																																																											
K	2004	(KE)DHS	Body	Dash Integration Module												V	V	V																																												
K	2004	(KE)DHS	Body	Digital Radio Receiver																																																											
K	2004	(KE)DHS	Body	Driver Door Switch																																																											
K	2004	(KE)DHS	Body	Driver Door Module																																																											
K	2004	(KE)DHS	Body	Passenger Door Module																																																											
K	2004	(KE)DHS	Body	Left Rear Door Module																																																											
K	2004	(KE)DHS	Body	Right Rear Door Module																																																											
K	2004	(KE)DHS	Body	Instrument Panel Cluster																																																											
K	2004	(KE)DHS	Body	Instrument Panel Module															V																																											
K	2004	(KE)DHS	Body	Memory Seat Module																																																											
K	2004	(KE)DHS	Body	Navigation Radio																V																																										
K	2004	(KE)DHS	Body	Radio																	V	V	V	V																																					
K	2004	(KE)DHS	Body	Rear Climate Control Panel																																																											
K	2004	(KE)DHS	Body	Rear Integration Module												V	V								V																																					

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2004	(KE)DHS	Body	Remote Function Actuation																																																												
K	2004	(KE)DHS	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KE)DHS	Body	Tilt Telescope Module																																																												
K	2004	(KE)DHS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module										V																																																	
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module											V																																																
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module										V																																																	
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module											V																																																
K	2004	(KF)DTS	Body	Amplifier (Bose)																																																												
K	2004	(KF)DTS	Body	CD Changer																																																												
K	2004	(KF)DTS	Body	Dash Integration Module												V	V	V																																													
K	2004	(KF)DTS	Body	Digital Radio Receiver																																																												
K	2004	(KF)DTS	Body	Driver Door Switch																																																												
K	2004	(KF)DTS	Body	Driver Door Module																																																												
K	2004	(KF)DTS	Body	Passenger Door Module																																																												
K	2004	(KF)DTS	Body	Left Rear Door Module																																																												
K	2004	(KF)DTS	Body	Right Rear Door Module																																																												
K	2004	(KF)DTS	Body	Instrument Panel Cluster																																																												
K	2004	(KF)DTS	Body	Instrument Panel Module															V																																												
K	2004	(KF)DTS	Body	Memory Seat Module																																																												
K	2004	(KF)DTS	Body	Navigation Radio																V																																											
K	2004	(KF)DTS	Body	Radio																	V	V	V	V																																							
K	2004	(KF)DTS	Body	Rear Climate Control Panel																																																												
K	2004	(KF)DTS	Body	Rear Integration Module												V	V								V																																						
K	2004	(KF)DTS	Body	Remote Function Actuation																																																												
K	2004	(KF)DTS	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KF)DTS	Body	Tilt Telescope Module																																																												
K	2004	(KF)DTS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Engine Control Module										V																																																	
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Transmission Control Module											V																																																
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module										V																																																	
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module											V																																																
K	2004	(KS)Seville SLS	Body	Amplifier (Bose)																																																												
K	2004	(KS)Seville SLS	Body	Amplifier (Delco)												V	V																																													
K	2004	(KS)Seville SLS	Body	CD Changer																																																												
K	2004	(KS)Seville SLS	Body	Dash Integration Module												V	V	V																																													
K	2004	(KS)Seville SLS	Body	Digital Radio Receiver																																																												
K	2004	(KS)Seville SLS	Body	Driver Door Module												V	V																																														
K	2004	(KS)Seville SLS	Body	Instrument Panel Cluster																																																												
K	2004	(KS)Seville SLS	Body	Instrument Panel Module															V																																												
K	2004	(KS)Seville SLS	Body	Memory Seat Module																																																												
K	2004	(KS)Seville SLS	Body	Navigation Radio																V																																											
K	2004	(KS)Seville SLS	Body	Radio																	V	V	V	V																																							
K	2004	(KS)Seville SLS	Body	Rear Integration Module												V	V																																														
K	2004	(KS)Seville SLS	Body	Remote Function Actuation																																																												
K	2004	(KS)Seville SLS	Body	Supplemental Inflatable Restraint												V	V																																														
K	2004	(KS)Seville SLS	Body	Tilt Telescope Module																																																												
K	2004	(KS)Seville SLS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Engine Control Module										V																																																	
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Transmission Control Module											V																																																
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module										V																																																	

| Engine type | Year | Model | System 1 | System 2 | Adjustable Pedals Data | Steering Column Softstops Learn | Steering Column Softstops Clear | Control Module Replacement Data | ECM Status Data | Key Fob Data | Keyless Entry Antenna - Center Console Active | Exterior Driver Side Keyless Entry Antenna | Exterior Passenger Side Keyless Entry Antenna | EGR Data | Clear TAP | Module Information 1 | Module Information 2 | A/C Information | HVAC Door Calibrations | Nav. Radio Theft | Cassette Information | CD Information | Long Wave | Military or Standard Time | Leveling Information | AIR Data | Navigation Voice | Invalidate all remote | Next available slot | TDM Data | Powertrain Status | Substitution Detection Data1 | Substitution Detection Data2 | Power Window Motor Programming | Stop/Start Capacitor State of Health Reset | Range Actuator | Range Actuator Learn | Rear Brake Caliper Piston Extend | Rear Brake Caliper Piston Retract | Battery Sensor Module Learn | Front Cameras Alignment Learn | Engineering Data 3 | Engineering Data 4 | Engineering Data 5 | Engineering Data 6 | Engineering Data 7 | Liftgate Maximum Open Position Learn | Clear Secured High Voltage DTCs | Battery Charger Control Module Data | Charge History Data | Contactor Data | Hybrid Battery Pack Contactor Open Reasons | Hybrid/EV Battery Pack Active Cooling | Hybrid/EV Powertrain Control Module 2 Data | Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn | Hybrid/EV Battery Pack Capacity Learn | Passenger Compartment Heater Coolant Control Solenoid Valve Learn | Fuel Economy Reset | Hybrid/EV Battery Contactor Open Reasons Reset | Hybrid/EV Battery Pack Charging Adaptive Learn Reset |
|---|---|---

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2005	(KE)DHS	Body	Passenger Door Module																																																												
K	2005	(KE)DHS	Body	Left Rear Door Module																																																												
K	2005	(KE)DHS	Body	Right Rear Door Module																																																												
K	2005	(KE)DHS	Body	Instrument Panel Cluster																																																												
K	2005	(KE)DHS	Body	Instrument Panel Module															V																																												
K	2005	(KE)DHS	Body	Memory Seat Module																																																												
K	2005	(KE)DHS	Body	Navigation Radio																V																																											
K	2005	(KE)DHS	Body	Radio																	V	V	V	V																																							
K	2005	(KE)DHS	Body	Rear Climate Control Panel																																																												
K	2005	(KE)DHS	Body	Rear Integration Module												V	V								V																																							
K	2005	(KE)DHS	Body	Remote Function Actuation																																																												
K	2005	(KE)DHS	Body	Supplemental Inflatable Restraint																																																												
K	2005	(KE)DHS	Body	Tilt Telescope Module																																																												
K	2005	(KE)DHS	Body	Vehicle Theft Deterrent																																																												
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module										V																																																	
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module											V																																																
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module										V																																																	
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module											V																																																
K	2005	(KF)DTS	Body	Amplifier (Bose)																																																												
K	2005	(KF)DTS	Body	CD Changer																																																												
K	2005	(KF)DTS	Body	Dash Integration Module												V	V	V																																													
K	2005	(KF)DTS	Body	Digital Radio Receiver																																																												
K	2005	(KF)DTS	Body	Driver Door Switch																																																												
K	2005	(KF)DTS	Body	Driver Door Module																																																												
K	2005	(KF)DTS	Body	Passenger Door Module																																																												
K	2005	(KF)DTS	Body	Left Rear Door Module																																																												
K	2005	(KF)DTS	Body	Right Rear Door Module																																																												
K	2005	(KF)DTS	Body	Instrument Panel Cluster																																																												
K	2005	(KF)DTS	Body	Instrument Panel Module															V																																												
K	2005	(KF)DTS	Body	Memory Seat Module																																																												
K	2005	(KF)DTS	Body	Navigation Radio																V																																											
K	2005	(KF)DTS	Body	Radio																	V	V	V	V																																							
K	2005	(KF)DTS	Body	Rear Climate Control Panel																																																												
K	2005	(KF)DTS	Body	Rear Integration Module												V	V								V																																							
K	2005	(KF)DTS	Body	Remote Function Actuation																																																												
K	2005	(KF)DTS	Body	Supplemental Inflatable Restraint																																																												
K	2005	(KF)DTS	Body	Tilt Telescope Module																																																												
K	2005	(KF)DTS	Body	Vehicle Theft Deterrent																																																												
K	2006	ALL	Powertrain	Engine Control Module										V												V																																							
K	2006	ALL	Powertrain	Automatic Transaxle																																																												
K	2006	ALL	Chassis	Antilock Brake System																																																												
K	2006	ALL	Body	Amplifier (Bose)																							V																																					
K	2006	ALL	Body	Aux. HVAC Control Module																																																												
K	2006	ALL	Body	Body Control Module																																																											
K	2006	ALL	Body	Digital Radio Receiver																																																												
K	2006	ALL	Body	Distance Sensing Cruise Control																																																												
K	2006	ALL	Body	Driver Door Switch																																																												
K	2006	ALL	Body	Driver Position Module																																																												
K	2006	ALL	Body	HVAC Control Module																																																												
K	2006	ALL	Body	Instrument Panel Cluster																																																												
K	2006	ALL	Body	Park Assist Module																																																												

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2006	ALL	Body	Passenger Door Switch																																																										
K	2006	ALL	Body	Passenger Presence System																																																										
K	2006	ALL	Body	Radio																																																										
K	2006	ALL	Body	Rear Heated Seat Module																																																										
K	2006	ALL	Body	Remote Control Door Lock Receiver																								V	V																																		
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2006	ALL	Body	Theft Deterrent Module																										V	V																																
K	2006	ALL	Body	TV Antenna Module																																																										
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																											
K	2007	ALL	Powertrain	Engine Control Module										V												V																																						
K	2007	ALL	Powertrain	Transmission Control Module																																																											
K	2007	ALL	Chassis	Electronic Brake Control Module																																																											
K	2007	ALL	Body	Amplifier (Bose)																							V																																					
K	2007	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																											
K	2007	ALL	Body	Body Control Module																																																											
K	2007	ALL	Body	Digital Radio Receiver																																																											
K	2007	ALL	Body	Distance Sensing Cruise Control																																																											
K	2007	ALL	Body	Driver Door Switch																																																											
K	2007	ALL	Body	Driver Position Module																																																											
K	2007	ALL	Body	CJ2 Dual Zone HVAC Auto																																																											
K	2007	ALL	Body	CJ4 Tri Zone HVAC Auto																																																											
K	2007	ALL	Body	Inside Rear View Mirror Module																																																											
K	2007	ALL	Body	Instrument Panel Cluster																																																											
K	2007	ALL	Body	Park Assist Module																																																											
K	2007	ALL	Body	Passenger Door Switch																																																											
K	2007	ALL	Body	Passenger Presence System																																																											
K	2007	ALL	Body	Radio																																																											
K	2007	ALL	Body	Rear Heated Seat Module																																																												
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2007	ALL	Body	Theft Deterrent Module																										V	V	V	V																														
K	2007	ALL	Body	TV Antenna Module																																																											
K	2007	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2008	ALL	Powertrain	Engine Control Module										V												V																																						
K	2008	ALL	Powertrain	Transmission Control Module																																																												
K	2008	ALL	Chassis	Electronic Brake Control Module																																																												
K	2008	ALL	Body	Amplifier (Bose)																																																												
K	2008	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																												
K	2008	ALL	Body	Body Control Module																																																											
K	2008	ALL	Body	Digital Radio Receiver																																																												
K	2008	ALL	Body	Distance Sensing Cruise Control																																																												
K	2008	ALL	Body	Driver Door Switch																														V																														
K	2008	ALL	Body	Driver Position Module																																																												
K	2008	ALL	Body	CJ2 Dual Zone HVAC Auto																																																												
K	2008	ALL	Body	CJ4 Tri Zone HVAC Auto																																																												
K	2008	ALL	Body	Inside Rear View Mirror Module																																																												
K	2008	ALL	Body	Instrument Panel Cluster																																																												
K	2008	ALL	Body	Left Side Object Detection Module																																																												
K	2008	ALL	Body	Park Assist Module																																																												
K	2008	ALL	Body	Passenger Door Switch																														V																														
K	2008	ALL	Body	Passenger Presence System																																																												
K	2008	ALL	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2008	ALL	Body	Rear Heated Seat Module																																																										
K	2008	ALL	Body	Right Side Object Detection Module																																																										
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2008	ALL	Body	Theft Deterrent Module																									V	V	V	V																														
K	2008	ALL	Body	TV Antenna Module																																																										
K	2008	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2008	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																										
K	2009	ALL	Powertrain	Engine Control Module										V												V																																					
K	2009	ALL	Powertrain	Transmission Control Module																																																											
K	2009	ALL	Chassis	Electronic Brake Control Module																																																											
K	2009	ALL	Body	Amplifier (Bose)																																																											
K	2009	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																											
K	2009	ALL	Body	Body Control Module																																																											
K	2009	ALL	Body	Digital Radio Receiver																																																											
K	2009	ALL	Body	Distance Sensing Cruise Control																																																											
K	2009	ALL	Body	Driver Door Switch																														V																														
K	2009	ALL	Body	Driver Position Module																																																											
K	2009	ALL	Body	CJ2 Dual Zone HVAC Auto																																																											
K	2009	ALL	Body	CJ4 Tri Zone HVAC Auto																																																											
K	2009	ALL	Body	Inside Rear View Mirror Module																																																											
K	2009	ALL	Body	Instrument Panel Cluster																																																											
K	2009	ALL	Body	Left Side Object Detection Module																																																											
K	2009	ALL	Body	Park Assist Module																																																											
K	2009	ALL	Body	Passenger Door Switch																														V																														
K	2009	ALL	Body	Passenger Presence System																																																											
K	2009	ALL	Body	Radio																																																										
K	2009	ALL	Body	Rear Heated Seat Module																																																											
K	2009	ALL	Body	Right Side Object Detection Module																																																											
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2009	ALL	Body	Theft Deterrent Module																									V	V	V	V																														
K	2009	ALL	Body	TV Antenna Module																																																											
K	2009	ALL	Body	Vehicle Comm. Interface Module																																																											
K	2009	ALL	Body	Vehicle Comm. Interface Module																																																											
K	2009	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																											
K	2010	ALL	Powertrain	Engine Control Module										V												V																																					
K	2010	ALL	Powertrain	Transmission Control Module																																																											
K	2010	ALL	Chassis	Electronic Brake Control Module																																																											
K	2010	ALL	Body	Amplifier (Bose)																																																											
K	2010	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																											
K	2010	ALL	Body	Body Control Module																																																											
K	2010	ALL	Body	Digital Radio Receiver																																																											
K	2010	ALL	Body	Distance Sensing Cruise Control																																																											
K	2010	ALL	Body	Driver Door Switch																														V																														
K	2010	ALL	Body	Driver Position Module																																																											
K	2010	ALL	Body	CJ2 Dual Zone HVAC Auto																																																											
K	2010	ALL	Body	CJ4 Tri Zone HVAC Auto																																																											
K	2010	ALL	Body	Inside Rear View Mirror Module																																																											
K	2010	ALL	Body	Instrument Panel Cluster																																																											
K	2010	ALL	Body	Left Side Object Detection Module																																																											
K	2010	ALL	Body	Park Assist Module																																																											
K	2010	ALL	Body	Passenger Door Switch																														V																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2010	ALL	Body	Passenger Presence System																																																									
K	2010	ALL	Body	Radio																																																									
K	2010	ALL	Body	Rear Heated Seat Module																																																									
K	2010	ALL	Body	Right Side Object Detection Module																																																									
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2010	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
K	2010	ALL	Body	TV Antenna Module																																																									
K	2010	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2010	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																									
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Engine Control Module										V												V																																			
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Transmission Control Module																																																									
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Engine Control Module										V												V																																			
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Transmission Control Module																																																									
K	2011	ALL	Chassis	Electronic Brake Control Module																																																									
K	2011	ALL	Body	Amplifier (Bose)																																																									
K	2011	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																									
K	2011	ALL	Body	Body Control Module																																																									
K	2011	ALL	Body	Digital Radio Receiver																																																									
K	2011	ALL	Body	Distance Sensing Cruise Control																																																									
K	2011	ALL	Body	Driver Door Switch																														V																											
K	2011	ALL	Body	Driver Position Module																																																									
K	2011	ALL	Body	CJ2 Dual Zone HVAC Auto																																																									
K	2011	ALL	Body	CJ4 Tri Zone HVAC Auto																																																									
K	2011	ALL	Body	Inside Rear View Mirror Module																																																									
K	2011	ALL	Body	Instrument Panel Cluster																																																									
K	2011	ALL	Body	Left Side Object Detection Module																																																									
K	2011	ALL	Body	Park Assist Module																																																									
K	2011	ALL	Body	Passenger Door Switch																														V																											
K	2011	ALL	Body	Passenger Presence System																																																									
K	2011	ALL	Body	Radio																																																									
K	2011	ALL	Body	Rear Heated Seat Module																																																									
K	2011	ALL	Body	Right Side Object Detection Module																																																									
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2011	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
K	2011	ALL	Body	TV Antenna Module																																																									
K	2011	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2011	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																									
K	2016	CT6	Powertrain	(X) 2.0L LTG Engine Control Module																															V																										
K	2016	CT6	Powertrain	(X) 2.0L LTG Transmission Control Module																																																									
K	2016	CT6	Powertrain	(6) 3.0L LGW Engine Control Module																																																									
K	2016	CT6	Powertrain	(6) 3.0L LGW Transmission Control Module																																																									
K	2016	CT6	Powertrain	(S) 3.6L LGX Engine Control Module																															V																										
K	2016	CT6	Powertrain	(S) 3.6L LGX Transmission Control Module																																																									
K	2016	CT6	Powertrain	Transfer Case Control Module																																V	V																								
K	2016	CT6	Chassis	Electronic Brake Control Module																																		V	V																						
K	2016	CT6	Chassis	Brake Booster Control Module																																																									
K	2016	CT6	Chassis	Power Steering Control Module																																																									
K	2016	CT6	Chassis	Rear Wheel Steering Control Module																																																									
K	2016	CT6	Chassis	Suspension Control Module																																																									
K	2016	CT6	Body	Body Control Module																																				V																					
K	2016	CT6	Body	Serial Data Gateway Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2016	CT6	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	CT6	Body	Passenger Presence Module																																																											
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Left																																																										
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Right																																																										
K	2016	CT6	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
K	2016	CT6	Body	Instrument Cluster Full Screen Display (UDV)																																																										
K	2016	CT6	Body	Radio Controls																																																										
K	2016	CT6	Body	HVAC Controls																																																										
K	2016	CT6	Body	Active Safety Control Module																																																										
K	2016	CT6	Body	Video Processing Control Module																																					V																						
K	2016	CT6	Body	Headlamp Control Module																																																										
K	2016	CT6	Body	Trailer Interface Control Module																																																										
K	2016	CT6	Body	Radio																																																										
K	2016	CT6	Body	Amplifier																																																										
K	2016	CT6	Body	Infotainment Control Touchpad																																																										
K	2016	CT6	Body	Human Machine Interface Control Module																																																										
K	2016	CT6	Body	Navigation Control Module																																																										
K	2016	CT6	Body	Telematics Communication Interface Control Module																																																										
K	2016	CT6	Body	HVAC Control Module																																																										
K	2016	CT6	Body	Liftgate Control Module																																						V	V	V	V	V	V															
K	2016	CT6	Body	Seat Memory Control Module - Passenger																																																										
K	2016	CT6	Body	Seat Memory Control Module - Left Rear																																																										
K	2016	CT6	Body	Seat Memory Control Module - Driver																																																										
K	2016	CT6	Body	Seat Memory Control Module - Right Rear																																																										
K	2016	CT6	Body	Keyless Entry Control Module																																																										
K	2016	CT6	Body	Left Side Object Detection Control Module																																																										
K	2016	CT6	Body	Parking Assist Control Module																																																										
K	2016	CT6	Body	Frontview Camera Module																																																										
K	2016	CT6	Body	Long Range Radar Sensor Module																																																										
K	2016	CT6	Body	Left Front Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Right Front Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Rear Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Night Vision Camera Control Module																																																										
R	2014	ELR	Powertrain	Engine Control Module																																																										
R	2014	ELR	Powertrain	Trasmission Control Module																																																										
R	2014	ELR	Powertrain	Chassis Control Module																																																										
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module																																													V													
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module 2																																													V	V	V	V	V	V	V	V	V	V	V	V	V
R	2014	ELR	Powertrain	Drive Motor Control Module 1																																																										
R	2014	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2014	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2014	ELR	Chassis	Electronic Brake Control Module																																																										
R	2014	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2014	ELR	Chassis	Parking Brake Control Module																																																										
R	2014	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2014	ELR	Chassis	Power Steering Control Module																																																										
R	2014	ELR	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2014	ELR	Chassis	Suspension Control Module																																																										
R	2014	ELR	Body	Body Control Module																																																										
R	2014	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2014	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2014	ELR	Body	Passenger Presence Module																																																										
R	2014	ELR	Body	Instrument Cluster																																																										
R	2014	ELR	Body	Radio/HVAC Control																																																										
R	2014	ELR	Body	Radio																																																										
R	2014	ELR	Body	Amplifier																																																										
R	2014	ELR	Body	Human Machine Interface Control Module																																																											
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2014	ELR	Body	HVAC Control Module																																																											
R	2014	ELR	Body	Electric A/C Compressor Control Module																																																											
R	2014	ELR	Body	Coolant Heater Control Module																																																											
R	2014	ELR	Body	Seat Memory Control Module - Driver																																																											
R	2014	ELR	Body	Keyless Entry Control Module																																																											
R	2014	ELR	Body	Right Side Object Detection Control Module																																																											
R	2014	ELR	Body	Left Side Object Detection Control Module																																																											
R	2014	ELR	Body	Parking Assist Control Module																																																											
R	2014	ELR	Body	Frontview Camera Module																																																											
R	2014	ELR	Body	Steering Column Lock Control Module																																																											
R	2014	ELR	Body	Battery Charger Control Module																																																											
R	2014	ELR	Body	Battery Energy Control Module																																																											
R	2015	ELR	Powertrain	Engine Control Module																																																											
R	2015	ELR	Powertrain	Trasmission Control Module																																																											
R	2015	ELR	Powertrain	Chassis Control Module																																																											
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module																																														V													
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module 2																																														V	V	V	V	V	V	V	V	V	V	V	V	V	V
R	2015	ELR	Powertrain	Drive Motor Control Module 1																																																											
R	2015	ELR	Powertrain	Drive Motor Control Module 2																																																											
R	2015	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2015	ELR	Chassis	Electronic Brake Control Module																																																											
R	2015	ELR	Chassis	Distance Sensing Cruise Control Module																																																											
R	2015	ELR	Chassis	Parking Brake Control Module																																																											
R	2015	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																											
R	2015	ELR	Chassis	Power Steering Control Module																																																											
R	2015	ELR	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2015	ELR	Chassis	Suspension Control Module																																																											
R	2015	ELR	Body	Body Control Module																																																											
R	2015	ELR	Body	Pedestrian Impact Detection Module																																																											
R	2015	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2015	ELR	Body	Passenger Presence Module																																																											
R	2015	ELR	Body	Instrument Cluster																																																											
R	2015	ELR	Body	Radio/HVAC Control																																																											
R	2015	ELR	Body	Headlamp Control Module																																																											
R	2015	ELR	Body	Radio																																																											
R	2015	ELR	Body	Amplifier																																																											
R	2015	ELR	Body	Human Machine Interface Control Module																																																											
R	2015	ELR	Body	Telematics Communication Interface Control Module																																																											
R	2015	ELR	Body	HVAC Control Module																																																											
R	2015	ELR	Body	Electric A/C Compressor Control Module																																																											
R	2015	ELR	Body	Coolant Heater Control Module																																																											
R	2015	ELR	Body	Seat Memory Control Module - Driver																																																											
R	2015	ELR	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2015	ELR	Body	Right Side Object Detection Control Module																																																										
R	2015	ELR	Body	Left Side Object Detection Control Module																																																										
R	2015	ELR	Body	Parking Assist Control Module																																																										
R	2015	ELR	Body	Frontview Camera Module																																																										
R	2015	ELR	Body	Steering Column Lock Control Module																																																										
R	2015	ELR	Body	Battery Charger Control Module																																																										
R	2015	ELR	Body	Battery Energy Control Module																																																										
R	2016	ELR	Powertrain	Engine Control Module																																																										
R	2016	ELR	Powertrain	Trasmission Control Module																																																										
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module																																														V													
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module 2																																														V	V	V	V	V	V	V	V	V	V	V	V	V
R	2016	ELR	Powertrain	Drive Motor Control Module 1																																																										
R	2016	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2016	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2016	ELR	Chassis	Electronic Brake Control Module																																																										
R	2016	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2016	ELR	Chassis	Parking Brake Control Module																																																										
R	2016	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2016	ELR	Chassis	Power Steering Control Module																																																										
R	2016	ELR	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2016	ELR	Chassis	Suspension Control Module																																																										
R	2016	ELR	Body	Body Control Module																																																										
R	2016	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2016	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	ELR	Body	Passenger Presence Module																																																										
R	2016	ELR	Body	Instrument Cluster																																																										
R	2016	ELR	Body	Radio/HVAC Control																																																										
R	2016	ELR	Body	Headlamp Control Module																																																										
R	2016	ELR	Body	Radio																																																										
R	2016	ELR	Body	Amplifier																																																										
R	2016	ELR	Body	Human Machine Interface Control Module																																																										
R	2016	ELR	Body	Telematics Communication Interface Control Module																																																										
R	2016	ELR	Body	HVAC Control Module																																																										
R	2016	ELR	Body	Electric A/C Compressor Control Module																																																										
R	2016	ELR	Body	Coolant Heater Control Module																																																										
R	2016	ELR	Body	Seat Memory Control Module - Driver																																																										
R	2016	ELR	Body	Keyless Entry Control Module																																																										
R	2016	ELR	Body	Left Side Object Detection Control Module																																																										
R	2016	ELR	Body	Parking Assist Control Module																																																										
R	2016	ELR	Body	Frontview Camera Module																																																										
R	2016	ELR	Body	Steering Column Lock Control Module																																																										
R	2016	ELR	Body	Battery Charger Control Module																																																										
R	2016	ELR	Body	Battery Energy Control Module																																																										
Y	2004	ALL	Powertrain	Engine Control Module																																																										
Y	2004	ALL	Powertrain	Automatic Transmission																																																										
Y	2004	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2004	ALL	Chassis	Electronic Suspension Control																																																										
Y	2004	ALL	Chassis	Steering Wheel and Column																																																										
Y	2004	ALL	Body	Amplifier (Bose)																																																										
Y	2004	ALL	Body	Body Control Module																																																										
Y	2004	ALL	Body	CD Changer																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Y	2004	ALL	Body	Digital Radio Receiver																																																										
Y	2004	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2004	ALL	Body	Driver Door Module																																																										
Y	2004	ALL	Body	Driver Door Switch																																																										
Y	2004	ALL	Body	Driver Position Module																																																										
Y	2004	ALL	Body	Folding Top Module																																																										
Y	2004	ALL	Body	Head Up Display																																																										
Y	2004	ALL	Body	HVAC Control Module																																																										
Y	2004	ALL	Body	Instrument Panel Cluster																																																										
Y	2004	ALL	Body	Navigation Radio																																																										
Y	2004	ALL	Body	Passenger Door Module																																																										
Y	2004	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2004	ALL	Body	Steering Column Lock Module																																																										
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2005	ALL	Powertrain	Engine Control Module																																																										
Y	2005	ALL	Powertrain	Automatic Transmission																																																										
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2005	ALL	Chassis	Electronic Suspension Control																																																										
Y	2005	ALL	Chassis	Steering Wheel and Column																																																										
Y	2005	ALL	Body	Amplifier (Bose)																																																										
Y	2005	ALL	Body	Body Control Module																																																										
Y	2005	ALL	Body	CD Changer																																																										
Y	2005	ALL	Body	Digital Radio Receiver																																																										
Y	2005	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2005	ALL	Body	Driver Door Module																																																										
Y	2005	ALL	Body	Driver Door Switch																																																										
Y	2005	ALL	Body	Driver Position Module																																																										
Y	2005	ALL	Body	Folding Top Module																																																										
Y	2005	ALL	Body	Head Up Display																																																										
Y	2005	ALL	Body	HVAC Control Module																																																										
Y	2005	ALL	Body	Instrument Panel Cluster																																																										
Y	2005	ALL	Body	Navigation Radio																																																										
Y	2005	ALL	Body	Passenger Door Module																																																										
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2005	ALL	Body	Steering Column Lock Module																																																										
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2006	(YV)XLR	Powertrain	Engine Control Module																																																										
Y	2006	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																										
Y	2006	(YV)XLR	Powertrain	Automatic Transmission																																																										
Y	2006	(YV)XLR	Chassis	Electronic Brake Control Module																																																										
Y	2006	(YV)XLR	Chassis	Electronic Suspension Control																																																										
Y	2006	(YV)XLR	Chassis	Steering Wheel and Column																																																										
Y	2006	(YV)XLR	Body	Amplifier (Bose)																																																										
Y	2006	(YV)XLR	Body	Body Control Module																																																										
Y	2006	(YV)XLR	Body	CD Changer																																																										
Y	2006	(YV)XLR	Body	Digital Radio Receiver																																																										
Y	2006	(YV)XLR	Body	Distance Sensing Cruise Control																																																										
Y	2006	(YV)XLR	Body	Driver Door Module																																																										
Y	2006	(YV)XLR	Body	Driver Door Switch																																																										
Y	2006	(YV)XLR	Body	Driver Position Module																																																										
Y	2006	(YV)XLR	Body	Folding Top Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Y	2006	(YV)XLR	Body	Headlamp Control Module																																																										
Y	2006	(YV)XLR	Body	Head Up Display																																																											
Y	2006	(YV)XLR	Body	HVAC Control Module																																																											
Y	2006	(YV)XLR	Body	Instrument Panel Cluster																																																											
Y	2006	(YV)XLR	Body	Navigation Radio																																																											
Y	2006	(YV)XLR	Body	Passenger Door Module																																																											
Y	2006	(YV)XLR	Body	Remote Control Door Lock Receiver																																																											
Y	2006	(YV)XLR	Body	Steering Column Lock Module																																																											
Y	2006	(YV)XLR	Body	Supplemental Inflatable Restraint																																																											
Y	2006	(YX)XLR-V	Powertrain	Engine Control Module																																																											
Y	2006	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																											
Y	2006	(YX)XLR-V	Powertrain	Automatic Transmission																																																											
Y	2006	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																											
Y	2006	(YX)XLR-V	Chassis	Electronic Suspension Control																																																											
Y	2006	(YX)XLR-V	Chassis	Steering Wheel and Column																																																											
Y	2006	(YX)XLR-V	Body	Amplifier (Bose)																																																											
Y	2006	(YX)XLR-V	Body	Body Control Module																																																											
Y	2006	(YX)XLR-V	Body	CD Changer																																																											
Y	2006	(YX)XLR-V	Body	Digital Radio Receiver																																																											
Y	2006	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																											
Y	2006	(YX)XLR-V	Body	Driver Door Module																																																											
Y	2006	(YX)XLR-V	Body	Driver Door Switch																																																											
Y	2006	(YX)XLR-V	Body	Driver Position Module																																																											
Y	2006	(YX)XLR-V	Body	Folding Top Module																																																											
Y	2006	(YX)XLR-V	Body	Headlamp Control Module																																																											
Y	2006	(YX)XLR-V	Body	Head Up Display																																																											
Y	2006	(YX)XLR-V	Body	HVAC Control Module																																																											
Y	2006	(YX)XLR-V	Body	Instrument Panel Cluster																																																											
Y	2006	(YX)XLR-V	Body	Navigation Radio																																																											
Y	2006	(YX)XLR-V	Body	Passenger Door Module																																																											
Y	2006	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																																											
Y	2006	(YX)XLR-V	Body	Steering Column Lock Module																																																											
Y	2006	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																											
Y	2007	(YV)XLR	Powertrain	Engine Control Module																																																											
Y	2007	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																											
Y	2007	(YV)XLR	Powertrain	Transmission Control Module																																																											
Y	2007	(YV)XLR	Chassis	Electronic Brake Control Module																																																											
Y	2007	(YV)XLR	Chassis	Electronic Suspension Control																																																											
Y	2007	(YV)XLR	Body	Amplifier (Bose)																																																											
Y	2007	(YV)XLR	Body	Body Control Module																																																											
Y	2007	(YV)XLR	Body	CD Changer																																																											
Y	2007	(YV)XLR	Body	Digital Radio Receiver																																																											
Y	2007	(YV)XLR	Body	Distance Sensing Cruise Control																																																											
Y	2007	(YV)XLR	Body	Driver Door Module																																																											
Y	2007	(YV)XLR	Body	Driver Door Switch																																																											
Y	2007	(YV)XLR	Body	Driver Position Module																																																											
Y	2007	(YV)XLR	Body	Folding Top Module																																																											
Y	2007	(YV)XLR	Body	Headlamp Control Module																																																											
Y	2007	(YV)XLR	Body	Head Up Display																																																											
Y	2007	(YV)XLR	Body	HVAC Control Module																																																											
Y	2007	(YV)XLR	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Y	2007	(YV)XLR	Body	Navigation Radio																																																									
Y	2007	(YV)XLR	Body	Passenger Door Module																																																										
Y	2007	(YV)XLR	Body	Remote Control Door Lock Receiver																																																										
Y	2007	(YV)XLR	Body	Steering Column Lock Module																																																										
Y	2007	(YV)XLR	Body	Supplemental Inflatable Restraint																																																										
Y	2007	(YX)XLR-V	Powertrain	Engine Control Module																																																										
Y	2007	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	(YX)XLR-V	Powertrain	Transmission Control Module																																																										
Y	2007	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																										
Y	2007	(YX)XLR-V	Chassis	Electronic Suspension Control																																																										
Y	2007	(YX)XLR-V	Body	Amplifier (Bose)																																																										
Y	2007	(YX)XLR-V	Body	Body Control Module																																																										
Y	2007	(YX)XLR-V	Body	CD Changer																																																										
Y	2007	(YX)XLR-V	Body	Digital Radio Receiver																																																										
Y	2007	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																										
Y	2007	(YX)XLR-V	Body	Driver Door Module																																																										
Y	2007	(YX)XLR-V	Body	Driver Door Switch																																																										
Y	2007	(YX)XLR-V	Body	Driver Position Module																																																										
Y	2007	(YX)XLR-V	Body	Folding Top Module																																																										
Y	2007	(YX)XLR-V	Body	Headlamp Control Module																																																										
Y	2007	(YX)XLR-V	Body	Head Up Display																																																										
Y	2007	(YX)XLR-V	Body	HVAC Control Module																																																										
Y	2007	(YX)XLR-V	Body	Instrument Panel Cluster																																																										
Y	2007	(YX)XLR-V	Body	Navigation Radio																																																										
Y	2007	(YX)XLR-V	Body	Passenger Door Module																																																										
Y	2007	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																																										
Y	2007	(YX)XLR-V	Body	Steering Column Lock Module																																																										
Y	2007	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2008	ALL	Chassis	Electronic Suspension Control																																																										
Y	2008	ALL	Body	Amplifier (Bose)																																																										
Y	2008	ALL	Body	Body Control Module																																																										
Y	2008	ALL	Body	CD Changer																																																										
Y	2008	ALL	Body	Digital Radio Receiver																																																										
Y	2008	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2008	ALL	Body	Driver Door Module																																																										
Y	2008	ALL	Body	Driver Door Switch																																																										
Y	2008	ALL	Body	Driver Position Module																																																										
Y	2008	ALL	Body	Folding Top Module																																																										
Y	2008	ALL	Body	Headlamp Control Module																																																										
Y	2008	ALL	Body	Head Up Display																																																										
Y	2008	ALL	Body	HVAC Control Module																																																										
Y	2008	ALL	Body	Instrument Panel Cluster																																																										
Y	2008	ALL	Body	Navigation Radio																																																										
Y	2008	ALL	Body	Passenger Door Module																																																										
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Y	2008	ALL	Body	Steering Column Lock Module																																																										
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Body	Vehicle Comm. Interface Module																																																										
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																										
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
Y	2009	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2009	ALL	Chassis	Electronic Suspension Control																																																										
Y	2009	ALL	Body	Amplifier (Bose)																																																										
Y	2009	ALL	Body	Body Control Module																																																										
Y	2009	ALL	Body	CD Changer																																																										
Y	2009	ALL	Body	Digital Radio Receiver																																																										
Y	2009	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2009	ALL	Body	Driver Door Module																																																										
Y	2009	ALL	Body	Driver Door Switch																																																										
Y	2009	ALL	Body	Driver Position Module																																																										
Y	2009	ALL	Body	Folding Top Module																																																										
Y	2009	ALL	Body	Headlamp Control Module																																																										
Y	2009	ALL	Body	Head Up Display																																																										
Y	2009	ALL	Body	HVAC Control Module																																																										
Y	2009	ALL	Body	Instrument Panel Cluster																																																										
Y	2009	ALL	Body	Navigation Radio																																																										
Y	2009	ALL	Body	Passenger Door Module																																																										
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2009	ALL	Body	Steering Column Lock Module																																																										
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
1	2013	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2013	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2013	XTS	Powertrain	Fuel Pump Control Module																																																										
1	2013	XTS	Powertrain	Rear Differential Clutch Control Module																																																										
1	2013	XTS	Chassis	Electronic Brake Control Module																																																										
1	2013	XTS	Chassis	Parking Brake Control Module																																																										
1	2013	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2013	XTS	Chassis	Power Steering Control Module																																																										
1	2013	XTS	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2013	XTS	Chassis	Suspension Control Module																																																										
1	2013	XTS	Body	Body Control Module																																																										
1	2013	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2013	XTS	Body	Passenger Presence Module																																																										
1	2013	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
1	2013	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
1	2013	XTS	Body	Radio/HVAC Control																																																										
1	2013	XTS	Body	Active Safety Control Module																																																										
1	2013	XTS	Body	Headlamp Control Module																																																										
1	2013	XTS	Body	Radio																																																										
1	2013	XTS	Body	Amplifier																																																										
1	2013	XTS	Body	Human Machine Interface Control Module																																																										
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2013	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2013	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
1	2013	XTS	Body	Seat Memory Control Module																																																											
1	2013	XTS	Body	Keyless Entry Control Module																																																											
1	2013	XTS	Body	Right Side Object Detection Control Module																																																											
1	2013	XTS	Body	Left Side Object Detection Control Module																																																											
1	2013	XTS	Body	Parking Assist Control Module																																																											
1	2013	XTS	Body	Frontview Camera Module																																																											
1	2013	XTS	Body	Long Range Radar Sensor Module																																																											
1	2013	XTS	Body	Left Front Short Range Radar Sensor Module																																																											
1	2013	XTS	Body	Right Front Short Range Radar Sensor Module																																																											
1	2013	XTS	Body	Rear Short Range Radar Sensor Module																																																											
1	2014	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
1	2014	XTS	Powertrain	(8) 3.6L LF3 Chassis Control Module																																																											
1	2014	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
1	2014	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2014	XTS	Powertrain	(3) 3.6L LFX Chassis Control Module																																																											
1	2014	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2014	XTS	Powertrain	Rear Differential Clutch Control Module																																																											
1	2014	XTS	Chassis	Electronic Brake Control Module																																																											
1	2014	XTS	Chassis	Parking Brake Control Module																																																											
1	2014	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2014	XTS	Chassis	Power Steering Control Module																																																											
1	2014	XTS	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	XTS	Chassis	Suspension Control Module																																																											
1	2014	XTS	Body	Body Control Module																																																											
1	2014	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	XTS	Body	Passenger Presence Module																																																											
1	2014	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
1	2014	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																											
1	2014	XTS	Body	Radio/HVAC Control																																																											
1	2014	XTS	Body	Active Safety Control Module																																																											
1	2014	XTS	Body	Headlamp Control Module																																																											
1	2014	XTS	Body	Radio																																																											
1	2014	XTS	Body	Amplifier																																																											
1	2014	XTS	Body	Media Disc Player																																																											
1	2014	XTS	Body	Human Machine Interface Control Module																																																											
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2014	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
1	2014	XTS	Body	Seat Memory Control Module - Passenger																																																											
1	2014	XTS	Body	Seat Memory Control Module - Driver																																																											
1	2014	XTS	Body	Keyless Entry Control Module																																																											
1	2014	XTS	Body	Right Side Object Detection Control Module																																																											
1	2014	XTS	Body	Left Side Object Detection Control Module																																																											
1	2014	XTS	Body	Parking Assist Control Module																																																											
1	2014	XTS	Body	Frontview Camera Module																																																											
1	2014	XTS	Body	Long Range Radar Sensor Module																																																											
1	2014	XTS	Body	Left Front Short Range Radar Sensor Module																																																											
1	2014	XTS	Body	Right Front Short Range Radar Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2014	XTS	Body	Rear Short Range Radar Sensor Module																																																											
1	2015	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
1	2015	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
1	2015	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2015	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2015	XTS	Powertrain	Chassis Control Module																																																											
1	2015	XTS	Powertrain	Rear Differential Clutch Control Module																																																											
1	2015	XTS	Chassis	Electronic Brake Control Module																																																											
1	2015	XTS	Chassis	Parking Brake Control Module																																																											
1	2015	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2015	XTS	Chassis	Power Steering Control Module																																																											
1	2015	XTS	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2015	XTS	Chassis	Suspension Control Module																																																											
1	2015	XTS	Body	Body Control Module																																																											
1	2015	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	XTS	Body	Passenger Presence Module																																																											
1	2015	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
1	2015	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																											
1	2015	XTS	Body	Radio/HVAC Control																																																											
1	2015	XTS	Body	Active Safety Control Module																																																											
1	2015	XTS	Body	Radio																																																											
1	2015	XTS	Body	Amplifier																																																											
1	2015	XTS	Body	Media Disc Player																																																											
1	2015	XTS	Body	Human Machine Interface Control Module																																																											
1	2015	XTS	Body	Telematics Communication Interface Control Module																																																											
1	2015	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2015	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
1	2015	XTS	Body	Seat Memory Control Module - Passenger																																																											
1	2015	XTS	Body	Seat Memory Control Module - Driver																																																											
1	2015	XTS	Body	Keyless Entry Control Module																																																											
1	2015	XTS	Body	Right Side Object Detection Control Module																																																											
1	2015	XTS	Body	Left Side Object Detection Control Module																																																											
1	2015	XTS	Body	Parking Assist Control Module GMLAN																																																											
1	2015	XTS	Body	Parking Assist Control Module DID72History																																																											
1	2015	XTS	Body	Frontview Camera Module																																																											
1	2015	XTS	Body	Long Range Radar Sensor Module																																																											
1	2015	XTS	Body	Left Front Short Range Radar Sensor Module																																																											
1	2015	XTS	Body	Right Front Short Range Radar Sensor Module																																																											
1	2015	XTS	Body	Rear Short Range Radar Sensor Module																																																											
1	2016	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
1	2016	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
1	2016	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2016	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2016	XTS	Powertrain	Chassis Control Module																																																											
1	2016	XTS	Powertrain	Rear Differential Clutch Control Module																																																											
1	2016	XTS	Chassis	Electronic Brake Control Module																																																											
1	2016	XTS	Chassis	Parking Brake Control Module																																																											
1	2016	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2016	XTS	Chassis	Power Steering Control Module																																																											
1	2016	XTS	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	XTS	Chassis	Suspension Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2016	XTS	Body	Body Control Module																																																											
1	2016	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2016	XTS	Body	Passenger Presence Module																																																												
1	2016	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
1	2016	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
1	2016	XTS	Body	Radio/HVAC Control																																																												
1	2016	XTS	Body	Active Safety Control Module																																																												
1	2016	XTS	Body	Video Processing Control Module																																					V																							
1	2016	XTS	Body	Radio																																																											
1	2016	XTS	Body	Amplifier																																																											
1	2016	XTS	Body	Media Disc Player																																																											
1	2016	XTS	Body	Human Machine Interface Control Module																																																											
1	2016	XTS	Body	Telematics Communication Interface Control Module																																																											
1	2016	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2016	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
1	2016	XTS	Body	Seat Memory Control Module - Passenger																																																											
1	2016	XTS	Body	Seat Memory Control Module - Driver																																																											
1	2016	XTS	Body	Keyless Entry Control Module																																																											
1	2016	XTS	Body	Right Side Object Detection Control Module																																																											
1	2016	XTS	Body	Left Side Object Detection Control Module																																																											
1	2016	XTS	Body	Parking Assist Control Module																																																											
1	2016	XTS	Body	Frontview Camera Module																																																											
1	2016	XTS	Body	Steering Column Lock Control Module																																																											
1	2016	XTS	Body	Long Range Radar Sensor Module																																																											
1	2016	XTS	Body	Left Front Short Range Radar Sensor Module																																																											
1	2016	XTS	Body	Right Front Short Range Radar Sensor Module																																																											
1	2016	XTS	Body	Rear Short Range Radar Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																													
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																													
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump																																																													
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																													
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Engine Mount																																																													
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																													
A	2013	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																													
A	2013	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																													
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump																																																													
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																													
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Engine Mount																																																													
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																													
A	2013	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																													
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																													
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump																																																													
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																													
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Engine Mount																																																													
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																													
A	2013	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
A	2013	ATS	Powertrain	Transfer Case Control Module																																																														
A	2013	ATS	Chassis	Electronic Brake Control Module																																																													
A	2013	ATS	Chassis	Parking Brake Control Module																																																													
A	2013	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																													
A	2013	ATS	Chassis	Power Steering Control Module																																																													
A	2013	ATS	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2013	ATS	Chassis	Suspension Control Module																																																													
A	2013	ATS	Body	Body Control Module Halogen																																																													
A	2013	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
A	2013	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2013	ATS	Body	Passenger Presence Module																																																													
A	2013	ATS	Body	Pedestrian Impact Detection Module																																																													
A	2013	ATS	Body	Instrument Cluster																																																													
A	2013	ATS	Body	Radio/HVAC Control																																																													
A	2013	ATS	Body	Active Safety Control Module																																																													
A	2013	ATS	Body	Headlamp Control Module																																																													
A	2013	ATS	Body	Trailer Interface Control Module																																																													
A	2013	ATS	Body	Radio																																																													
A	2013	ATS	Body	Amplifier																																																													
A	2013	ATS	Body	Human Machine Interface Control Module																																																													
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 9																																																													
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 10																																																													
A	2013	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
A	2013	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																													
A	2013	ATS	Body	Seat Memory Control Module																																																													
A	2013	ATS	Body	Keyless Entry Type Without Passive Entry																																																													
A	2013	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																													
A	2013	ATS	Body	Right Side Object Detection Control Module																																																													
A	2013	ATS	Body	Left Side Object Detection Control Module																																																													
A	2013	ATS	Body	Parking Assist Control Module																																																													
A	2013	ATS	Body	Frontview Camera Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2013	ATS	Body	Steering Column Lock Control Module																																																														
A	2013	ATS	Body	Long Range Radar Sensor Module																																																														
A	2013	ATS	Body	Left Front Short Range Radar Sensor Module																																																													
A	2013	ATS	Body	Right Front Short Range Radar Sensor Module																																																													
A	2013	ATS	Body	Rear Short Range Radar Sensor Module																																																													
A	2014	ATS	Powertrain	(X) 2.0L LTG Engine Control Module																																																													
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
A	2014	ATS	Powertrain	Transfer Case Control Module																																																													
A	2014	ATS	Chassis	Electronic Brake Control Module																																																													
A	2014	ATS	Chassis	Parking Brake Control Module																																																													
A	2014	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																													
A	2014	ATS	Chassis	Power Steering Control Module																																																													
A	2014	ATS	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2014	ATS	Chassis	Suspension Control Module																																																													
A	2014	ATS	Body	Body Control Module Halogen																																																													
A	2014	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
A	2014	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2014	ATS	Body	Passenger Presence Module																																																													
A	2014	ATS	Body	Pedestrian Impact Detection Module																																																													
A	2014	ATS	Body	Instrument Cluster																																																													
A	2014	ATS	Body	Radio/HVAC Control																																																													
A	2014	ATS	Body	Active Safety Control Module																																																													
A	2014	ATS	Body	Headlamp Control Module																																																													
A	2014	ATS	Body	Trailer Interface Control Module																																																													
A	2014	ATS	Body	Radio																																																													
A	2014	ATS	Body	Amplifier																																																													
A	2014	ATS	Body	Media Disc Player																																																													
A	2014	ATS	Body	Human Machine Interface Control Module																																																													
A	2014	ATS	Body	Navigation Control Module																																																													
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 9																																																													
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 10																																																													
A	2014	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
A	2014	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																													
A	2014	ATS	Body	Seat Memory Control Module - Driver																																																													
A	2014	ATS	Body	Keyless Entry Type Without Passive Entry																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2014	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																													
A	2014	ATS	Body	Right Side Object Detection Control Module																																																														
A	2014	ATS	Body	Left Side Object Detection Control Module																																																													
A	2014	ATS	Body	Parking Assist Control Module																																																													
A	2014	ATS	Body	Frontview Camera Module																																																													
A	2014	ATS	Body	Steering Column Lock Control Module																																																													
A	2014	ATS	Body	Long Range Radar Sensor Module																																																													
A	2014	ATS	Body	Left Front Short Range Radar Sensor Module																																																													
A	2014	ATS	Body	Right Front Short Range Radar Sensor Module																																																													
A	2014	ATS	Body	Rear Short Range Radar Sensor Module																																																													
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																													
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Maunal Transmission																																																													
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																													
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																													
A	2014	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																													
A	2014	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																														
A	2014	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																													
A	2014	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																													
A	2014	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																													
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																													
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																													
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																													
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																													
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																													
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																													
A	2014	CTS	Powertrain	Transfer Case Control Module																																																														
A	2014	CTS	Chassis	Electronic Brake Control Module																																																														
A	2014	CTS	Chassis	Parking Brake Control Module																																																														
A	2014	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																														
A	2014	CTS	Chassis	Power Steering Control Module																																																														
A	2014	CTS	Chassis	Steering Wheel Angle Sensor Module																																																														
A	2014	CTS	Chassis	Suspension Control Module																																																														
A	2014	CTS	Body	Body Control Module Headlamp Type Halogen																																																														
A	2014	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
A	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2014	CTS	Body	Passenger Presence Module																																																														
A	2014	CTS	Body	Pedestrian Impact Detection Module																																																														
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Left																																																														
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Right																																																														
A	2014	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																														
A	2014	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																														
A	2014	CTS	Body	Radio/HVAC Control																																																														
A	2014	CTS	Body	Active Safety Control Module																																																														
A	2014	CTS	Body	Headlamp Control Module																																																														
A	2014	CTS	Body	Trailer Interface Control Module																																																														
A	2014	CTS	Body	Radio																																																														
A	2014	CTS	Body	Amplifier																																																														
A	2014	CTS	Body	Human Machine Interface Control Module																																																														
A	2014	CTS	Body	Navigation Control Module																																																														
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																														
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2014	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
A	2014	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																														
A	2014	CTS	Body	Seat Memory Control Module - Driver																																																														
A	2014	CTS	Body	Keyless Entry Control Module																																																														
A	2014	CTS	Body	Right Side Object Detection Control Module																																																														
A	2014	CTS	Body	Left Side Object Detection Control Module																																																														
A	2014	CTS	Body	Parking Assist Control Module																																																														
A	2014	CTS	Body	Frontview Camera Module																																																														
A	2014	CTS	Body	Steering Column Lock Control Module																																																														
A	2014	CTS	Body	Long Range Radar Sensor Module																																																														
A	2014	CTS	Body	Left Front Short Range Radar Sensor Module																																																														
A	2014	CTS	Body	Right Front Short Range Radar Sensor Module																																																														
A	2014	CTS	Body	Rear Short Range Radar Sensor Module																																																														
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																														
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																														
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																														
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																														
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																														
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																														
A	2015	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																														
A	2015	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																														
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																														
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																														
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																														
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																														
A	2015	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																														
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																														
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																														
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																														
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																														
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																														
A	2015	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
A	2015	ATS	Powertrain	Transfer Case Control Module																																																															
A	2015	ATS	Chassis	Electronic Brake Control Module																																																															
A	2015	ATS	Chassis	Parking Brake Control Module																																																															
A	2015	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																															
A	2015	ATS	Chassis	Power Steering Control Module																																																															
A	2015	ATS	Chassis	Steering Wheel Angle Sensor Module																																																															
A	2015	ATS	Chassis	Suspension Control Module																																																															
A	2015	ATS	Body	Body Control Module Halogen																																																															
A	2015	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																															
A	2015	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
A	2015	ATS	Body	Passenger Presence Module																																																															
A	2015	ATS	Body	Pedestrian Impact Detection Module																																																															
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Left																																																															
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Right																																																															
A	2015	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																															
A	2015	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																															
A	2015	ATS	Body	Radio/HVAC Control																																																															
A	2015	ATS	Body	Active Safety Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2015	ATS	Body	Headlamp Control Module																																																														
A	2015	ATS	Body	Trailer Interface Control Module																																																														
A	2015	ATS	Body	Radio																																																														
A	2015	ATS	Body	Amplifier																																																														
A	2015	ATS	Body	Media Disc Player																																																														
A	2015	ATS	Body	Human Machine Interface Control Module																																																														
A	2015	ATS	Body	Navigation Control Module																																																														
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																														
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 10																																																														
A	2015	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
A	2015	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																														
A	2015	ATS	Body	Seat Memory Control Module - Driver																																																														
A	2015	ATS	Body	Keyless Entry Control Module Coupe																																																														
A	2015	ATS	Body	Keyless Entry Control Module Sadan																																																														
A	2015	ATS	Body	Right Side Object Detection Control Module																																																														
A	2015	ATS	Body	Left Side Object Detection Control Module																																																														
A	2015	ATS	Body	Parking Assist Control Module																																																														
A	2015	ATS	Body	Frontview Camera Module																																																														
A	2015	ATS	Body	Steering Column Lock Control Module																																																														
A	2015	ATS	Body	Long Range Radar Sensor Module																																																														
A	2015	ATS	Body	Left Front Short Range Radar Sensor Module																																																														
A	2015	ATS	Body	Right Front Short Range Radar Sensor Module																																																														
A	2015	ATS	Body	Rear Short Range Radar Sensor Module																																																														
A	2015	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																														
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Engine Mount																																																														
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																														
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																														
A	2015	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																														
A	2015	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																														
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																														
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Fuel Pump and Engine Mount																																																														
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Active Grile Air Shutter And Engine Mount																																																														
A	2015	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																														
A	2015	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																														
A	2015	CTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Engine Mount																																																														
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																														
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																														
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																														
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																														
A	2015	CTS	Powertrain	Transfer Case Control Module																																																														
A	2015	CTS	Chassis	Electronic Brake Control Module																																																														
A	2015	CTS	Chassis	Parking Brake Control Module																																																														
A	2015	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																														
A	2015	CTS	Chassis	Power Steering Control Module																																																														
A	2015	CTS	Chassis	Steering Wheel Angle Sensor Module																																																														
A	2015	CTS	Chassis	Suspension Control Module																																																														
A	2015	CTS	Body	Body Control Module Headlamp Type Halogen																																																														
A	2015	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
A	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
A	2015	CTS	Body	Passenger Presence Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2015	CTS	Body	Pedestrian Impact Detection Module																																																														
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Left																																																														
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Right																																																														
A	2015	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																														
A	2015	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																														
A	2015	CTS	Body	Active Safety Control Module																																																														
A	2015	CTS	Body	Trailer Interface Control Module																																																														
A	2015	CTS	Body	Radio																																																														
A	2015	CTS	Body	Amplifier																																																														
A	2015	CTS	Body	Human Machine Interface Control Module																																																														
A	2015	CTS	Body	Navigation Control Module																																																														
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																														
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																														
A	2015	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
A	2015	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																														
A	2015	CTS	Body	Seat Memory Control Module - Driver																																																														
A	2015	CTS	Body	Keyless Entry Control Module																																																														
A	2015	CTS	Body	Right Side Object Detection Control Module																																																														
A	2015	CTS	Body	Left Side Object Detection Control Module																																																														
A	2015	CTS	Body	Parking Assist Control Module																																																														
A	2015	CTS	Body	Frontview Camera Module																																																														
A	2015	CTS	Body	Steering Column Lock Control Module																																																														
A	2015	CTS	Body	Long Range Radar Sensor Module																																																														
A	2015	CTS	Body	Left Front Short Range Radar Sensor Module																																																														
A	2015	CTS	Body	Right Front Short Range Radar Sensor Module																																																														
A	2015	CTS	Body	Rear Short Range Radar Sensor Module																																																														
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																														
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																														
A	2016	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																														
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																														
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																														
A	2016	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Automatic Transmission																																																														
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Manual Transmission																																																														
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Transmission Control Module																																																														
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																														
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																														
A	2016	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
A	2016	ATS	Powertrain	Transfer Case Control Module																																																														
A	2016	ATS	Powertrain	Rear Differential Clutch Control Module																																																														
A	2016	ATS	Chassis	Electronic Brake Control Module																																																														
A	2016	ATS	Chassis	Parking Brake Control Module																																																														
A	2016	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																														
A	2016	ATS	Chassis	Power Steering Control Module																																																														
A	2016	ATS	Chassis	Steering Wheel Angle Sensor Module																																																														
A	2016	ATS	Chassis	Suspension Control Module																																																														
A	2016	ATS	Body	Body Control Module Halogen																																																														
A	2016	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
A	2016	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
A	2016	ATS	Body	Passenger Presence Module																																																														
A	2016	ATS	Body	Pedestrian Impact Detection Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Left																																																															
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Right																																																															
A	2016	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																															
A	2016	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																															
A	2016	ATS	Body	Radio/HVAC Control																																																															
A	2016	ATS	Body	Vehicle Performance Data Recorder																																																															
A	2016	ATS	Body	Trailer Interface Control Module																																																															
A	2016	ATS	Body	Radio																																																															
A	2016	ATS	Body	Amplifier																																																															
A	2016	ATS	Body	Rear Audio Control Module																																																															
A	2016	ATS	Body	Media Disc Player																																																															
A	2016	ATS	Body	Human Machine Interface Control Module																																																															
A	2016	ATS	Body	Navigation Control Module																																																															
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																															
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 10																																																															
A	2016	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
A	2016	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																															
A	2016	ATS	Body	Seat Memory Control Module - Passenger																																																															
A	2016	ATS	Body	Seat Memory Control Module - Driver																																																															
A	2016	ATS	Body	Keyless Entry Control Module Coupe																																																															
A	2016	ATS	Body	Keyless Entry Control Module Sadan																																																															
A	2016	ATS	Body	Right Side Object Detection Control Module																																																															
A	2016	ATS	Body	Left Side Object Detection Control Module																																																															
A	2016	ATS	Body	Parking Assist Control Module																																																															
A	2016	ATS	Body	Frontview Camera Module																																																															
A	2016	ATS	Body	Steering Column Lock Control Module																																																															
A	2016	ATS	Body	Long Range Radar Sensor Module																																																															
A	2016	ATS	Body	Left Front Short Range Radar Sensor Module																																																															
A	2016	ATS	Body	Right Front Short Range Radar Sensor Module																																																															
A	2016	ATS	Body	Rear Short Range Radar Sensor Module																																																															
A	2016	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																															
A	2016	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																															
A	2016	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																															
A	2016	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																															
A	2016	CTS	Powertrain	(S) 3.6L LGX Engine Control Module																																																															
A	2016	CTS	Powertrain	(S) 3.6L LGX Transmission Control Module																																																															
A	2016	CTS	Powertrain	(6) 6.2L LT4 Engine Control Module																																																															
A	2016	CTS	Powertrain	(6) 6.2L LT4 Transmission Control Module																																																															
A	2016	CTS	Powertrain	Rear Differential Clutch Control Module																																																															
A	2016	CTS	Powertrain	Transfer Case Control Module																																																															
A	2016	CTS	Chassis	Electronic Brake Control Module																																																															
A	2016	CTS	Chassis	Parking Brake Control Module																																																															
A	2016	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																															
A	2016	CTS	Chassis	Power Steering Control Module																																																															
A	2016	CTS	Chassis	Steering Wheel Angle Sensor Module																																																															
A	2016	CTS	Chassis	Suspension Control Module																																																															
A	2016	CTS	Body	Body Control Module Headlamp Type Halogen																																																															
A	2016	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																															
A	2016	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
A	2016	CTS	Body	Passenger Presence Module																																																															
A	2016	CTS	Body	Pedestrian Impact Detection Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Left																																																															
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Right																																																															
A	2016	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																															
A	2016	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																															
A	2016	CTS	Body	Radio/HVAC Control																																																															
A	2016	CTS	Body	Vehicle Performance Data Recorder																																																															
A	2016	CTS	Body	Active Safety Control Module																																																															
A	2016	CTS	Body	Video Processing Control Module																																																															
A	2016	CTS	Body	Trailer Interface Control Module																																																															
A	2016	CTS	Body	Radio																																																															
A	2016	CTS	Body	Amplifier																																																															
A	2016	CTS	Body	Human Machine Interface Control Module																																																															
A	2016	CTS	Body	Navigation Control Module																																																															
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																															
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 10																																																															
A	2016	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
A	2016	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																															
A	2016	CTS	Body	Seat Memory Control Module - Passenger																																																															
A	2016	CTS	Body	Seat Memory Control Module - Driver																																																															
A	2016	CTS	Body	Keyless Entry Control Module																																																															
A	2016	CTS	Body	Right Side Object Detection Control Module																																																															
A	2016	CTS	Body	Left Side Object Detection Control Module																																																															
A	2016	CTS	Body	Parking Assist Control Module																																																															
A	2016	CTS	Body	Frontview Camera Module																																																															
A	2016	CTS	Body	Steering Column Lock Control Module																																																															
A	2016	CTS	Body	Long Range Radar Sensor Module																																																															
A	2016	CTS	Body	Left Front Short Range Radar Sensor Module																																																															
A	2016	CTS	Body	Right Front Short Range Radar Sensor Module																																																															
A	2016	CTS	Body	Rear Short Range Radar Sensor Module																																																															
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																															
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																															
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																															
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																															
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																															
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																															
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																															
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																															
D	2004	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																															
D	2004	(DM)CTS	Chassis	VES																																																															
D	2004	(DM)CTS	Body	Amplifier (Bose)																																																															
D	2004	(DM)CTS	Body	Amplifier (Delco)																																																															
D	2004	(DM)CTS	Body	Climate Control Panel																																																															
D	2004	(DM)CTS	Body	Dash Integration Module																																																															
D	2004	(DM)CTS	Body	Digital Radio Receiver																																																															
D	2004	(DM)CTS	Body	Driver Door Switch																																																															
D	2004	(DM)CTS	Body	Driver Door Module																																																															
D	2004	(DM)CTS	Body	Passenger Door Module																																																															
D	2004	(DM)CTS	Body	Left Rear Door Module																																																															
D	2004	(DM)CTS	Body	Right Rear Door Module																																																															
D	2004	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																															
D	2004	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2004	(DM)CTS	Body	Instrument Panel Cluster																																																																
D	2004	(DM)CTS	Body	Memory Seat Module																																																																
D	2004	(DM)CTS	Body	Personalization																																																																
D	2004	(DM)CTS	Body	Rear Integration Module																																																																
D	2004	(DM)CTS	Body	Remote Function Actuation																																																																
D	2004	(DM)CTS	Body	Supplemental Inflatable Restraint																																																																
D	2004	(DM)CTS	Body	TV Antenna Module																																																																
D	2004	(DM)CTS	Body	Vehicle Theft Deterrent																																																																
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																																
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																																
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																																
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																																
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																																
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																																
D	2004	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																																
D	2004	(DR)CTS	Chassis	VES																																																																
D	2004	(DR)CTS	Body	Amplifier (Bose)																																																																
D	2004	(DR)CTS	Body	Amplifier (Delco)																																																																
D	2004	(DR)CTS	Body	Climate Control Panel																																																																
D	2004	(DR)CTS	Body	Dash Integration Module																																																																
D	2004	(DR)CTS	Body	Digital Radio Receiver																																																																
D	2004	(DR)CTS	Body	Driver Door Switch																																																																
D	2004	(DR)CTS	Body	Driver Door Module																																																																
D	2004	(DR)CTS	Body	Passenger Door Module																																																																
D	2004	(DR)CTS	Body	Left Rear Door Module																																																																
D	2004	(DR)CTS	Body	Right Rear Door Module																																																																
D	2004	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																																
D	2004	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																																
D	2004	(DR)CTS	Body	Instrument Panel Cluster																																																																
D	2004	(DR)CTS	Body	Memory Seat Module																																																																
D	2004	(DR)CTS	Body	Personalization																																																																
D	2004	(DR)CTS	Body	Rear Integration Module																																																																
D	2004	(DR)CTS	Body	Remote Function Actuation																																																																
D	2004	(DR)CTS	Body	Supplemental Inflatable Restraint																																																																
D	2004	(DR)CTS	Body	TV Antenna Module																																																																
D	2004	(DR)CTS	Body	Vehicle Theft Deterrent																																																																
D	2004	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																																
D	2004	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																																
D	2004	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																																
D	2004	(DN)CTS-V	Chassis	VES																																																																
D	2004	(DN)CTS-V	Body	Amplifier (Bose)																																																																
D	2004	(DN)CTS-V	Body	Amplifier (Delco)																																																																
D	2004	(DN)CTS-V	Body	Climate Control Panel																																																																
D	2004	(DN)CTS-V	Body	Dash Integration Module																																																																
D	2004	(DN)CTS-V	Body	Digital Radio Receiver																																																																
D	2004	(DN)CTS-V	Body	Driver Door Switch																																																																
D	2004	(DN)CTS-V	Body	Driver Door Module																																																																
D	2004	(DN)CTS-V	Body	Passenger Door Module																																																																
D	2004	(DN)CTS-V	Body	Left Rear Door Module																																																																
D	2004	(DN)CTS-V	Body	Right Rear Door Module																																																																
D	2004	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																																

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2004	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																													
D	2004	(DN)CTS-V	Body	Instrument Panel Cluster																																																													
D	2004	(DN)CTS-V	Body	Memory Seat Module																																																													
D	2004	(DN)CTS-V	Body	Personalization																																																													
D	2004	(DN)CTS-V	Body	Rear Integration Module																																																													
D	2004	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																													
D	2004	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																													
D	2004	(DN)CTS-V	Body	TV Antenna Module																																																													
D	2004	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																													
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																													
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																													
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
D	2005	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																													
D	2005	(DM)CTS	Chassis	VES																																																													
D	2005	(DM)CTS	Body	Amplifier (Bose)																																																													
D	2005	(DM)CTS	Body	Amplifier (Delco)																																																													
D	2005	(DM)CTS	Body	Climate Control Panel																																																													
D	2005	(DM)CTS	Body	Dash Integration Module																																																													
D	2005	(DM)CTS	Body	Digital Radio Receiver																																																													
D	2005	(DM)CTS	Body	Driver Door Switch																																																													
D	2005	(DM)CTS	Body	Driver Door Module																																																													
D	2005	(DM)CTS	Body	Passenger Door Module																																																													
D	2005	(DM)CTS	Body	Left Rear Door Module																																																													
D	2005	(DM)CTS	Body	Right Rear Door Module																																																													
D	2005	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																													
D	2005	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																													
D	2005	(DM)CTS	Body	Instrument Panel Cluster																																																													
D	2005	(DM)CTS	Body	Memory Seat Module																																																													
D	2005	(DM)CTS	Body	Personalization																																																													
D	2005	(DM)CTS	Body	Rear Integration Module																																																													
D	2005	(DM)CTS	Body	Remote Control Door Lock Receiver																																																													
D	2005	(DM)CTS	Body	Supplemental Inflatable Restraint																																																													
D	2005	(DM)CTS	Body	TV Antenna Module																																																													
D	2005	(DM)CTS	Body	Vehicle Theft Deterrent																																																													
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																													
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																													
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
D	2005	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																													
D	2005	(DP)CTS	Chassis	VES																																																													
D	2005	(DP)CTS	Body	Amplifier (Bose)																																																													
D	2005	(DP)CTS	Body	Amplifier (Delco)																																																													
D	2005	(DP)CTS	Body	Climate Control Panel																																																													
D	2005	(DP)CTS	Body	Dash Integration Module																																																													
D	2005	(DP)CTS	Body	Digital Radio Receiver																																																													
D	2005	(DP)CTS	Body	Driver Door Switch																																																													
D	2005	(DP)CTS	Body	Driver Door Module																																																													
D	2005	(DP)CTS	Body	Passenger Door Module																																																													
D	2005	(DP)CTS	Body	Left Rear Door Module																																																													
D	2005	(DP)CTS	Body	Right Rear Door Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2005	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																															
D	2005	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																															
D	2005	(DP)CTS	Body	Instrument Panel Cluster																																																															
D	2005	(DP)CTS	Body	Memory Seat Module																																																															
D	2005	(DP)CTS	Body	Personalization																																																															
D	2005	(DP)CTS	Body	Rear Integration Module																																																															
D	2005	(DP)CTS	Body	Remote Control Door Lock Receiver																																																															
D	2005	(DP)CTS	Body	Supplemental Inflatable Restraint																																																														
D	2005	(DP)CTS	Body	TV Antenna Module																																																															
D	2005	(DP)CTS	Body	Vehicle Theft Deterrent																																																															
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																															
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																															
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																															
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																															
D	2005	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																															
D	2005	(DR)CTS	Chassis	VES																																																															
D	2005	(DR)CTS	Body	Amplifier (Bose)																																																															
D	2005	(DR)CTS	Body	Amplifier (Delco)																																																															
D	2005	(DR)CTS	Body	Climate Control Panel																																																															
D	2005	(DR)CTS	Body	Dash Integration Module																																																															
D	2005	(DR)CTS	Body	Digital Radio Receiver																																																															
D	2005	(DR)CTS	Body	Driver Door Switch																																																															
D	2005	(DR)CTS	Body	Driver Door Module																																																															
D	2005	(DR)CTS	Body	Passenger Door Module																																																															
D	2005	(DR)CTS	Body	Left Rear Door Module																																																															
D	2005	(DR)CTS	Body	Right Rear Door Module																																																															
D	2005	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																															
D	2005	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																															
D	2005	(DR)CTS	Body	Instrument Panel Cluster																																																															
D	2005	(DR)CTS	Body	Memory Seat Module																																																															
D	2005	(DR)CTS	Body	Personalization																																																															
D	2005	(DR)CTS	Body	Radio																																																															
D	2005	(DR)CTS	Body	Rear Integration Module																																																															
D	2005	(DR)CTS	Body	Remote Control Door Lock Receiver																																																															
D	2005	(DR)CTS	Body	Supplemental Inflatable Restraint																																																														
D	2005	(DR)CTS	Body	TV Antenna Module																																																															
D	2005	(DR)CTS	Body	Vehicle Theft Deterrent																																																															
D	2005	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																															
D	2005	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																															
D	2005	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																															
D	2005	(DN)CTS-V	Chassis	VES																																																															
D	2005	(DN)CTS-V	Body	Amplifier (Bose)																																																															
D	2005	(DN)CTS-V	Body	Amplifier (Delco)																																																															
D	2005	(DN)CTS-V	Body	Climate Control Panel																																																															
D	2005	(DN)CTS-V	Body	Dash Integration Module																																																															
D	2005	(DN)CTS-V	Body	Digital Radio Receiver																																																															
D	2005	(DN)CTS-V	Body	Driver Door Switch																																																															
D	2005	(DN)CTS-V	Body	Driver Door Module																																																															
D	2005	(DN)CTS-V	Body	Passenger Door Module																																																															
D	2005	(DN)CTS-V	Body	Left Rear Door Module																																																															
D	2005	(DN)CTS-V	Body	Right Rear Door Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2005	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																														
D	2005	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																															
D	2005	(DN)CTS-V	Body	Instrument Panel Cluster																																																															
D	2005	(DN)CTS-V	Body	Memory Seat Module																																																															
D	2005	(DN)CTS-V	Body	Personalization																																																															
D	2005	(DN)CTS-V	Body	Radio																																																															
D	2005	(DN)CTS-V	Body	Rear Integration Module																																																															
D	2005	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																															
D	2005	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																															
D	2005	(DN)CTS-V	Body	TV Antenna Module																																																															
D	2005	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																															
D	2005	(DC)STS-V8	Powertrain	Engine Control Module																																																															
D	2005	(DC)STS-V8	Powertrain	Transmission Control Module																																																															
D	2005	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																															
D	2005	(DC)STS-V8	Chassis	Electronic Suspension Control																																																															
D	2005	(DC)STS-V8	Body	Amplifier (Bose)																																																															
D	2005	(DC)STS-V8	Body	Digital Radio Receiver																																																															
D	2005	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																															
D	2005	(DC)STS-V8	Body	Driver Door Module																																																															
D	2005	(DC)STS-V8	Body	Driver Door Switch																																																															
D	2005	(DC)STS-V8	Body	Driver Position Module																																																															
D	2005	(DC)STS-V8	Body	Headlamp Control Module																																																															
D	2005	(DC)STS-V8	Body	Head Up Display																																																															
D	2005	(DC)STS-V8	Body	HVAC Control Module																																																															
D	2005	(DC)STS-V8	Body	Instrument Panel Cluster																																																															
D	2005	(DC)STS-V8	Body	Instrument Panel Module																																																															
D	2005	(DC)STS-V8	Body	Left Rear Door Module																																																															
D	2005	(DC)STS-V8	Body	Passenger Door Module																																																															
D	2005	(DC)STS-V8	Body	Uplevel Radio																																																															
D	2005	(DC)STS-V8	Body	Navigation Radio																																																															
D	2005	(DC)STS-V8	Body	Rear Integration Module																																																															
D	2005	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																															
D	2005	(DC)STS-V8	Body	Right Rear Door Module																																																															
D	2005	(DC)STS-V8	Body	Steering Column Lock Module																																																															
D	2005	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																															
D	2005	(DC)STS-V8	Body	TV Antenna Module																																																															
D	2005	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																															
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																															
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																															
D	2005	(DW)STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																															
D	2005	(DW)STS	Chassis	Electronic Brake Control Module																																																															
D	2005	(DW)STS	Chassis	Electronic Suspension Control																																																															
D	2005	(DW)STS	Body	Amplifier (Bose)																																																															
D	2005	(DW)STS	Body	Digital Radio Receiver																																																															
D	2005	(DW)STS	Body	Distance Sensing Cruise Control																																																															
D	2005	(DW)STS	Body	Driver Door Module																																																															
D	2005	(DW)STS	Body	Driver Door Switch																																																															
D	2005	(DW)STS	Body	Driver Position Module																																																															
D	2005	(DW)STS	Body	Headlamp Control Module																																																															
D	2005	(DW)STS	Body	Head Up Display																																																															
D	2005	(DW)STS	Body	HVAC Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2005	(DW)STS	Body	Instrument Panel Cluster																																																														
D	2005	(DW)STS	Body	Instrument Panel Module																																																														
D	2005	(DW)STS	Body	Left Rear Door Module																																																													
D	2005	(DW)STS	Body	Passenger Door Module																																																													
D	2005	(DW)STS	Body	Uplevel Radio																																																													
D	2005	(DW)STS	Body	Navigation Radio																																																													
D	2005	(DW)STS	Body	Rear Integration Module																																																													
D	2005	(DW)STS	Body	Remote Control Door Lock Receiver																																																													
D	2005	(DW)STS	Body	Right Rear Door Module																																																													
D	2005	(DW)STS	Body	Steering Column Lock Module																																																													
D	2005	(DW)STS	Body	Supplemental Inflatable Restraint																																																													
D	2005	(DW)STS	Body	TV Antenna Module																																																													
D	2005	(DW)STS	Body	Vehicle Comm. Interface Module																																																													
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																													
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																													
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
D	2006	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																													
D	2006	(DM)CTS	Chassis	Tire Pressure Monitor																																																													
D	2006	(DM)CTS	Chassis	VES																																																													
D	2006	(DM)CTS	Body	Amplifier (Bose)																																																													
D	2006	(DM)CTS	Body	Amplifier (Delco)																																																													
D	2006	(DM)CTS	Body	Climate Control Panel																																																													
D	2006	(DM)CTS	Body	Dash Integration Module																																																													
D	2006	(DM)CTS	Body	Digital Radio Receiver																																																													
D	2006	(DM)CTS	Body	Driver Door Switch																																																													
D	2006	(DM)CTS	Body	Driver Door Module																																																													
D	2006	(DM)CTS	Body	Passenger Door Module																																																													
D	2006	(DM)CTS	Body	Left Rear Door Module																																																													
D	2006	(DM)CTS	Body	Right Rear Door Module																																																													
D	2006	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																													
D	2006	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																													
D	2006	(DM)CTS	Body	Instrument Panel Cluster																																																													
D	2006	(DM)CTS	Body	Memory Seat Module																																																													
D	2006	(DM)CTS	Body	Personalization																																																													
D	2006	(DM)CTS	Body	Radio																																																													
D	2006	(DM)CTS	Body	Rear Integration Module																																																													
D	2006	(DM)CTS	Body	Remote Control Door Lock Receiver																																																													
D	2006	(DM)CTS	Body	Supplemental Inflatable Restraint																																																													
D	2006	(DM)CTS	Body	TV Antenna Module																																																													
D	2006	(DM)CTS	Body	Vehicle Theft Deterrent																																																													
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																													
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																													
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
D	2006	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																													
D	2006	(DP)CTS	Chassis	Tire Pressure Monitor																																																													
D	2006	(DP)CTS	Chassis	VES																																																													
D	2006	(DP)CTS	Body	Amplifier (Bose)																																																													
D	2006	(DP)CTS	Body	Amplifier (Delco)																																																													
D	2006	(DP)CTS	Body	Climate Control Panel																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2006	(DP)CTS	Body	Dash Integration Module																																																																
D	2006	(DP)CTS	Body	Digital Radio Receiver																																																																
D	2006	(DP)CTS	Body	Driver Door Switch																																																																
D	2006	(DP)CTS	Body	Driver Door Module																																																																
D	2006	(DP)CTS	Body	Passenger Door Module																																																																
D	2006	(DP)CTS	Body	Left Rear Door Module																																																																
D	2006	(DP)CTS	Body	Right Rear Door Module																																																																
D	2006	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																																
D	2006	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																																
D	2006	(DP)CTS	Body	Instrument Panel Cluster																																																																
D	2006	(DP)CTS	Body	Memory Seat Module																																																																
D	2006	(DP)CTS	Body	Personalization																																																																
D	2006	(DP)CTS	Body	Radio																																																																
D	2006	(DP)CTS	Body	Rear Integration Module																																																																
D	2006	(DP)CTS	Body	Remote Control Door Lock Receiver																																																																
D	2006	(DP)CTS	Body	Supplemental Inflatable Restraint																																																															
D	2006	(DP)CTS	Body	TV Antenna Module																																																																
D	2006	(DP)CTS	Body	Vehicle Theft Deterrent																																																																
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																																
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																																
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																																
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																																
D	2006	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																																
D	2006	(DR)CTS	Chassis	Tire Pressure Monitor																																																																
D	2006	(DR)CTS	Chassis	VES																																																																
D	2006	(DR)CTS	Body	Amplifier (Bose)																																																																
D	2006	(DR)CTS	Body	Amplifier (Delco)																																																																
D	2006	(DR)CTS	Body	Climate Control Panel																																																																
D	2006	(DR)CTS	Body	Dash Integration Module																																																																
D	2006	(DR)CTS	Body	Digital Radio Receiver																																																																
D	2006	(DR)CTS	Body	Driver Door Switch																																																																
D	2006	(DR)CTS	Body	Driver Door Module																																																																
D	2006	(DR)CTS	Body	Passenger Door Module																																																																
D	2006	(DR)CTS	Body	Left Rear Door Module																																																																
D	2006	(DR)CTS	Body	Right Rear Door Module																																																																
D	2006	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																																
D	2006	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																																
D	2006	(DR)CTS	Body	Instrument Panel Cluster																																																																
D	2006	(DR)CTS	Body	Memory Seat Module																																																																
D	2006	(DR)CTS	Body	Personalization																																																																
D	2006	(DR)CTS	Body	Radio																																																																
D	2006	(DR)CTS	Body	Rear Integration Module																																																																
D	2006	(DR)CTS	Body	Remote Control Door Lock Receiver																																																																
D	2006	(DR)CTS	Body	Supplemental Inflatable Restraint																																																															
D	2006	(DR)CTS	Body	TV Antenna Module																																																																
D	2006	(DR)CTS	Body	Vehicle Theft Deterrent																																																																
D	2006	(DN)CTS-V	Powertrain	Engine Control Module																																																																
D	2006	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																																
D	2006	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																																
D	2006	(DN)CTS-V	Chassis	VES																																																																
D	2006	(DN)CTS-V	Body	Amplifier (Bose)																																																																

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2006	(DN)CTS-V	Body	Amplifier (Delco)																																																														
D	2006	(DN)CTS-V	Body	Climate Control Panel																																																															
D	2006	(DN)CTS-V	Body	Dash Integration Module																																																															
D	2006	(DN)CTS-V	Body	Digital Radio Receiver																																																															
D	2006	(DN)CTS-V	Body	Driver Door Switch																																																															
D	2006	(DN)CTS-V	Body	Driver Door Module																																																															
D	2006	(DN)CTS-V	Body	Passenger Door Module																																																															
D	2006	(DN)CTS-V	Body	Left Rear Door Module																																																															
D	2006	(DN)CTS-V	Body	Right Rear Door Module																																																															
D	2006	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																															
D	2006	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																															
D	2006	(DN)CTS-V	Body	Instrument Panel Cluster																																																															
D	2006	(DN)CTS-V	Body	Memory Seat Module																																																															
D	2006	(DN)CTS-V	Body	Personalization																																																															
D	2006	(DN)CTS-V	Body	Rear Integration Module																																																															
D	2006	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																															
D	2006	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																														
D	2006	(DN)CTS-V	Body	TV Antenna Module																																																															
D	2006	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																														
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Engine Controls																																																														
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																														
D	2006	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																														
D	2006	(DC)STS-V8	Chassis	Electronic Suspension Control																																																														
D	2006	(DC)STS-V8	Body	Amplifier (Bose)																																																														
D	2006	(DC)STS-V8	Body	Digital Radio Receiver																																																														
D	2006	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																														
D	2006	(DC)STS-V8	Body	Driver Door Module																																																														
D	2006	(DC)STS-V8	Body	Driver Door Switch																																																														
D	2006	(DC)STS-V8	Body	Driver Position Module																																																														
D	2006	(DC)STS-V8	Body	Headlamp Control Module																																																														
D	2006	(DC)STS-V8	Body	Head Up Display																																																														
D	2006	(DC)STS-V8	Body	HVAC Control Module																																																														
D	2006	(DC)STS-V8	Body	Instrument Panel Cluster																																																														
D	2006	(DC)STS-V8	Body	Instrument Panel Module																																																														
D	2006	(DC)STS-V8	Body	Left Rear Door Module																																																														
D	2006	(DC)STS-V8	Body	Passenger Door Module																																																														
D	2006	(DC)STS-V8	Body	Uplevel Radio																																																														
D	2006	(DC)STS-V8	Body	Navigation Radio																																																														
D	2006	(DC)STS-V8	Body	Rear Integration Module																																																														
D	2006	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																														
D	2006	(DC)STS-V8	Body	Right Rear Door Module																																																														
D	2006	(DC)STS-V8	Body	Steering Column Lock Module																																																														
D	2006	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																														
D	2006	(DC)STS-V8	Body	TV Antenna Module																																																														
D	2006	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																														
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																														
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
D	2006	(DW)STS	Chassis	Electronic Brake Control Module																																																														
D	2006	(DW)STS	Chassis	Electronic Suspension Control																																																														
D	2006	(DW)STS	Body	Amplifier (Bose)																																																														
D	2006	(DW)STS	Body	Digital Radio Receiver																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2006	(DW)STS	Body	Distance Sensing Cruise Control																																																														
D	2006	(DW)STS	Body	Driver Door Module																																																														
D	2006	(DW)STS	Body	Driver Door Switch																																																														
D	2006	(DW)STS	Body	Driver Position Module																																																														
D	2006	(DW)STS	Body	Headlamp Control Module																																																														
D	2006	(DW)STS	Body	Head Up Display																																																														
D	2006	(DW)STS	Body	HVAC Control Module																																																														
D	2006	(DW)STS	Body	Instrument Panel Cluster																																																														
D	2006	(DW)STS	Body	Instrument Panel Module																																																														
D	2006	(DW)STS	Body	Left Rear Door Module																																																														
D	2006	(DW)STS	Body	Passenger Door Module																																																														
D	2006	(DW)STS	Body	Uplevel Radio																																																														
D	2006	(DW)STS	Body	Navigation Radio																																																														
D	2006	(DW)STS	Body	Rear Integration Module																																																														
D	2006	(DW)STS	Body	Remote Control Door Lock Receiver																																																														
D	2006	(DW)STS	Body	Right Rear Door Module																																																														
D	2006	(DW)STS	Body	Steering Column Lock Module																																																														
D	2006	(DW)STS	Body	Supplemental Inflatable Restraint																																																														
D	2006	(DW)STS	Body	TV Antenna Module																																																														
D	2006	(DW)STS	Body	Vehicle Comm. Interface Module																																																														
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																														
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																														
D	2006	(DX)STS-V	Chassis	Electronic Brake Control Module																																																														
D	2006	(DX)STS-V	Chassis	Electronic Suspension Control																																																														
D	2006	(DX)STS-V	Body	Amplifier (Bose)																																																														
D	2006	(DX)STS-V	Body	Digital Radio Receiver																																																														
D	2006	(DX)STS-V	Body	Distance Sensing Cruise Control																																																														
D	2006	(DX)STS-V	Body	Driver Door Module																																																														
D	2006	(DX)STS-V	Body	Driver Door Switch																																																														
D	2006	(DX)STS-V	Body	Driver Position Module																																																														
D	2006	(DX)STS-V	Body	Headlamp Control Module																																																														
D	2006	(DX)STS-V	Body	Head Up Display																																																														
D	2006	(DX)STS-V	Body	HVAC Control Module																																																														
D	2006	(DX)STS-V	Body	Instrument Panel Cluster																																																														
D	2006	(DX)STS-V	Body	Instrument Panel Module																																																														
D	2006	(DX)STS-V	Body	Left Rear Door Module																																																														
D	2006	(DX)STS-V	Body	Passenger Door Module																																																														
D	2006	(DX)STS-V	Body	Uplevel Radio																																																														
D	2006	(DX)STS-V	Body	Navigation Radio																																																														
D	2006	(DX)STS-V	Body	Rear Integration Module																																																														
D	2006	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																														
D	2006	(DX)STS-V	Body	Right Rear Door Module																																																														
D	2006	(DX)STS-V	Body	Steering Column Lock Module																																																														
D	2006	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																														
D	2006	(DX)STS-V	Body	TV Antenna Module																																																														
D	2006	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																														
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																														
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																														
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																														
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																														
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
D	2007	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																														
D	2007	(DM)CTS	Chassis	VES																																																														
D	2007	(DM)CTS	Body	Amplifier (Bose)																																																														
D	2007	(DM)CTS	Body	Amplifier (Delco)																																																														
D	2007	(DM)CTS	Body	Climate Control Panel																																																														
D	2007	(DM)CTS	Body	Dash Integration Module																																																														
D	2007	(DM)CTS	Body	Digital Radio Receiver																																																														
D	2007	(DM)CTS	Body	Driver Door Switch																																																														
D	2007	(DM)CTS	Body	Driver Door Module																																																														
D	2007	(DM)CTS	Body	Passenger Door Module																																																														
D	2007	(DM)CTS	Body	Left Rear Door Module																																																														
D	2007	(DM)CTS	Body	Right Rear Door Module																																																														
D	2007	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																														
D	2007	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																														
D	2007	(DM)CTS	Body	Instrument Panel Cluster																																																														
D	2007	(DM)CTS	Body	Memory Seat Module																																																														
D	2007	(DM)CTS	Body	Personalization																																																														
D	2007	(DM)CTS	Body	Rear Integration Module																																																														
D	2007	(DM)CTS	Body	Remote Control Door Lock Receiver																																																														
D	2007	(DM)CTS	Body	Supplemental Inflatable Restraint																																																													
D	2007	(DM)CTS	Body	Theft Deterrent Module																																																													
D	2007	(DM)CTS	Body	TV Antenna Module																																																														
D	2007	(DM)CTS	Body	Vehicle Comm. Interface Module																																																														
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																														
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																														
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																														
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																														
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																														
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
D	2007	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																														
D	2007	(DP)CTS	Chassis	VES																																																														
D	2007	(DP)CTS	Body	Amplifier (Bose)																																																														
D	2007	(DP)CTS	Body	Amplifier (Delco)																																																														
D	2007	(DP)CTS	Body	Climate Control Panel																																																														
D	2007	(DP)CTS	Body	Dash Integration Module																																																														
D	2007	(DP)CTS	Body	Digital Radio Receiver																																																														
D	2007	(DP)CTS	Body	Driver Door Switch																																																														
D	2007	(DP)CTS	Body	Driver Door Module																																																														
D	2007	(DP)CTS	Body	Passenger Door Module																																																														
D	2007	(DP)CTS	Body	Left Rear Door Module																																																														
D	2007	(DP)CTS	Body	Right Rear Door Module																																																														
D	2007	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																														
D	2007	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																														
D	2007	(DP)CTS	Body	Instrument Panel Cluster																																																														
D	2007	(DP)CTS	Body	Memory Seat Module																																																														
D	2007	(DP)CTS	Body	Personalization																																																														
D	2007	(DP)CTS	Body	Rear Integration Module																																																														
D	2007	(DP)CTS	Body	Remote Control Door Lock Receiver																																																														
D	2007	(DP)CTS	Body	Supplemental Inflatable Restraint																																																													
D	2007	(DP)CTS	Body	Theft Deterrent Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2007	(DP)CTS	Body	TV Antenna Module																																																															
D	2007	(DP)CTS	Body	Vehicle Comm. Interface Module																																																															
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																															
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																															
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																															
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																															
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																															
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																															
D	2007	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																															
D	2007	(DR)CTS	Chassis	VES																																																															
D	2007	(DR)CTS	Body	Amplifier (Bose)																																																															
D	2007	(DR)CTS	Body	Amplifier (Delco)																																																															
D	2007	(DR)CTS	Body	Climate Control Panel																																																															
D	2007	(DR)CTS	Body	Dash Integration Module																																																															
D	2007	(DR)CTS	Body	Digital Radio Receiver																																																															
D	2007	(DR)CTS	Body	Driver Door Switch																																																															
D	2007	(DR)CTS	Body	Driver Door Module																																																															
D	2007	(DR)CTS	Body	Passenger Door Module																																																															
D	2007	(DR)CTS	Body	Left Rear Door Module																																																															
D	2007	(DR)CTS	Body	Right Rear Door Module																																																															
D	2007	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																															
D	2007	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																															
D	2007	(DR)CTS	Body	Instrument Panel Cluster																																																															
D	2007	(DR)CTS	Body	Memory Seat Module																																																															
D	2007	(DR)CTS	Body	Personalization																																																															
D	2007	(DR)CTS	Body	Rear Integration Module																																																															
D	2007	(DR)CTS	Body	Remote Control Door Lock Receiver																																																															
D	2007	(DR)CTS	Body	Supplemental Inflatable Restraint																																																														
D	2007	(DR)CTS	Body	Theft Deterrent Module																																																															
D	2007	(DR)CTS	Body	TV Antenna Module																																																															
D	2007	(DR)CTS	Body	Vehicle Comm. Interface Module																																																															
D	2007	(DN)CTS-V	Powertrain	(U)6.0L V8 LS2 Engine Control Module																																																															
D	2007	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																															
D	2007	(DN)CTS-V	Chassis	VES																																																															
D	2007	(DN)CTS-V	Body	Amplifier (Bose)																																																															
D	2007	(DN)CTS-V	Body	Amplifier (Delco)																																																															
D	2007	(DN)CTS-V	Body	Climate Control Panel																																																															
D	2007	(DN)CTS-V	Body	Dash Integration Module																																																															
D	2007	(DN)CTS-V	Body	Digital Radio Receiver																																																															
D	2007	(DN)CTS-V	Body	Driver Door Switch																																																															
D	2007	(DN)CTS-V	Body	Driver Door Module																																																															
D	2007	(DN)CTS-V	Body	Passenger Door Module																																																															
D	2007	(DN)CTS-V	Body	Left Rear Door Module																																																															
D	2007	(DN)CTS-V	Body	Right Rear Door Module																																																															
D	2007	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																															
D	2007	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																															
D	2007	(DN)CTS-V	Body	Instrument Panel Cluster																																																															
D	2007	(DN)CTS-V	Body	Memory Seat Module																																																															
D	2007	(DN)CTS-V	Body	Personalization																																																															
D	2007	(DN)CTS-V	Body	Rear Integration Module																																																															
D	2007	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2007	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																														
D	2007	(DN)CTS-V	Body	Theft Deterrent Module																																																															
D	2007	(DN)CTS-V	Body	TV Antenna Module																																																															
D	2007	(DN)CTS-V	Body	Vehicle Comm. Interface Module																																																															
D	2007	(DC)STS-V8	Powertrain	Engine Control Module																																																															
D	2007	(DC)STS-V8	Powertrain	Transmission Control Module																																																															
D	2007	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																															
D	2007	(DC)STS-V8	Chassis	Electronic Suspension Control																																																															
D	2007	(DC)STS-V8	Body	Amplifier (Bose)																																																															
D	2007	(DC)STS-V8	Body	Digital Radio Receiver																																																															
D	2007	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																															
D	2007	(DC)STS-V8	Body	Driver Door Module																																																															
D	2007	(DC)STS-V8	Body	Driver Door Switch																																																															
D	2007	(DC)STS-V8	Body	Driver Position Module																																																															
D	2007	(DC)STS-V8	Body	Headlamp Control Module																																																															
D	2007	(DC)STS-V8	Body	Head Up Display																																																															
D	2007	(DC)STS-V8	Body	HVAC Control Module																																																															
D	2007	(DC)STS-V8	Body	Instrument Panel Cluster																																																															
D	2007	(DC)STS-V8	Body	Instrument Panel Module																																																															
D	2007	(DC)STS-V8	Body	Left Rear Door Module																																																															
D	2007	(DC)STS-V8	Body	Passenger Door Module																																																															
D	2007	(DC)STS-V8	Body	Uplevel Radio																																																															
D	2007	(DC)STS-V8	Body	Navigation Radio																																																															
D	2007	(DC)STS-V8	Body	Rear Integration Module																																																															
D	2007	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																															
D	2007	(DC)STS-V8	Body	Right Rear Door Module																																																															
D	2007	(DC)STS-V8	Body	Steering Column Lock Module																																																															
D	2007	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																															
D	2007	(DC)STS-V8	Body	TV Antenna Module																																																															
D	2007	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																															
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																															
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																															
D	2007	(DW)STS	Chassis	Electronic Brake Control Module																																																															
D	2007	(DW)STS	Chassis	Electronic Suspension Control																																																															
D	2007	(DW)STS	Body	Amplifier (Bose)																																																															
D	2007	(DW)STS	Body	Digital Radio Receiver																																																															
D	2007	(DW)STS	Body	Distance Sensing Cruise Control																																																															
D	2007	(DW)STS	Body	Driver Door Module																																																															
D	2007	(DW)STS	Body	Driver Door Switch																																																															
D	2007	(DW)STS	Body	Driver Position Module																																																															
D	2007	(DW)STS	Body	Headlamp Control Module																																																															
D	2007	(DW)STS	Body	Head Up Display																																																															
D	2007	(DW)STS	Body	HVAC Control Module																																																															
D	2007	(DW)STS	Body	Instrument Panel Cluster																																																															
D	2007	(DW)STS	Body	Instrument Panel Module																																																															
D	2007	(DW)STS	Body	Left Rear Door Module																																																															
D	2007	(DW)STS	Body	Passenger Door Module																																																															
D	2007	(DW)STS	Body	Uplevel Radio																																																															
D	2007	(DW)STS	Body	Navigation Radio																																																															
D	2007	(DW)STS	Body	Rear Integration Module																																																															
D	2007	(DW)STS	Body	Remote Control Door Lock Receiver																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2007	(DW)STS	Body	Right Rear Door Module																																																															
D	2007	(DW)STS	Body	Steering Column Lock Module																																																															
D	2007	(DW)STS	Body	Supplemental Inflatable Restraint																																																															
D	2007	(DW)STS	Body	TV Antenna Module																																																															
D	2007	(DW)STS	Body	Vehicle Comm. Interface Module																																																															
D	2007	(DX)STS-V	Powertrain	Engine Control Module																																																															
D	2007	(DX)STS-V	Powertrain	Transmission Control Module																																																															
D	2007	(DX)STS-V	Chassis	Electronic Brake Control Module																																																															
D	2007	(DX)STS-V	Chassis	Electronic Suspension Control																																																															
D	2007	(DX)STS-V	Body	Amplifier (Bose)																																																															
D	2007	(DX)STS-V	Body	Digital Radio Receiver																																																															
D	2007	(DX)STS-V	Body	Distance Sensing Cruise Control																																																															
D	2007	(DX)STS-V	Body	Driver Door Module																																																															
D	2007	(DX)STS-V	Body	Driver Door Switch																																																															
D	2007	(DX)STS-V	Body	Driver Position Module																																																															
D	2007	(DX)STS-V	Body	Headlamp Control Module																																																															
D	2007	(DX)STS-V	Body	Head Up Display																																																															
D	2007	(DX)STS-V	Body	HVAC Control Module																																																															
D	2007	(DX)STS-V	Body	Instrument Panel Cluster																																																															
D	2007	(DX)STS-V	Body	Instrument Panel Module																																																															
D	2007	(DX)STS-V	Body	Left Rear Door Module																																																															
D	2007	(DX)STS-V	Body	Passenger Door Module																																																															
D	2007	(DX)STS-V	Body	Uplevel Radio																																																															
D	2007	(DX)STS-V	Body	Navigation Radio																																																															
D	2007	(DX)STS-V	Body	Rear Integration Module																																																															
D	2007	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																															
D	2007	(DX)STS-V	Body	Right Rear Door Module																																																															
D	2007	(DX)STS-V	Body	Steering Column Lock Module																																																															
D	2007	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																															
D	2007	(DX)STS-V	Body	TV Antenna Module																																																															
D	2007	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																															
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																															
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																															
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																															
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																															
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																															
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																															
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																															
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																															
D	2008	CTS	Chassis	Electronic Brake Control Module																																																															
D	2008	CTS	Body	Body Control Module																																																															
D	2008	CTS	Body	Body Control Module (aux.)																																																															
D	2008	CTS	Body	Driver Door Switch																																																															
D	2008	CTS	Body	Headlamp Control Module																																																															
D	2008	CTS	Body	HVAC Control Module																																																															
D	2008	CTS	Body	Infotainment Faceplate Module																																																															
D	2008	CTS	Body	Instrument Panel Cluster																																																															
D	2008	CTS	Body	Memory Seat Module																																																															
D	2008	CTS	Body	Park Assist Module																																																															
D	2008	CTS	Body	Passenger Door Switch																																																															
D	2008	CTS	Body	Passenger Presence System																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2008	CTS	Body	Pedestrian Impact Detection Module																																																														
D	2008	CTS	Body	Radio																																																														
D	2008	CTS	Body	Supplemental Inflatable Restraint																																																														
D	2008	CTS	Body	TV Antenna Module																																																														
D	2008	CTS	Body	Vehicle Comm. Interface Module																																																														
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																														
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																														
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																														
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																														
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																														
D	2008	SLS	Chassis	Electronic Brake Control Module																																																														
D	2008	SLS	Chassis	Electronic Suspension Control																																																														
D	2008	SLS	Body	Amplifier (Bose)																																																														
D	2008	SLS	Body	Driver Door Module																																																														
D	2008	SLS	Body	Driver Door Switch																																																														
D	2008	SLS	Body	Driver Position Module																																																														
D	2008	SLS	Body	Headlamp Control Module																																																														
D	2008	SLS	Body	HVAC Control Module																																																														
D	2008	SLS	Body	Instrument Panel Cluster																																																														
D	2008	SLS	Body	Instrument Panel Module																																																														
D	2008	SLS	Body	Left Rear Door Module																																																														
D	2008	SLS	Body	Passenger Door Module																																																														
D	2008	SLS	Body	Radio																																																														
D	2008	SLS	Body	Rear HVAC/RSA																																																														
D	2008	SLS	Body	Rear Integration Module																																																														
D	2008	SLS	Body	Remote Control Door Lock Receiver																																																														
D	2008	SLS	Body	Right Rear Door Module																																																														
D	2008	SLS	Body	Supplemental Inflatable Restraint																																																														
D	2008	SLS	Body	TV Antenna Module																																																														
D	2008	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																														
D	2008	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																														
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																														
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																														
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																														
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																														
D	2008	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																														
D	2008	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																														
D	2008	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																														
D	2008	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																														
D	2008	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																														
D	2008	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																														
D	2008	STS	Body	Amplifier (Bose)																																																														
D	2008	STS	Body	Digital Radio Receiver																																																														
D	2008	STS	Body	Distance Sensing Cruise Control																																																														
D	2008	STS	Body	Driver Door Module																																																														
D	2008	STS	Body	Driver Door Switch																																																														
D	2008	STS	Body	Driver Position Module																																																														
D	2008	STS	Body	Headlamp Control Module																																																														
D	2008	STS	Body	Head Up Display																																																														
D	2008	STS	Body	HVAC Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2008	STS	Body	Instrument Panel Cluster																																																														
D	2008	STS	Body	Instrument Panel Module																																																															
D	2008	STS	Body	Left Rear Door Module																																																															
D	2008	STS	Body	Left Side Object Detection Module																																																															
D	2008	STS	Body	Passenger Door Module																																																															
D	2008	STS	Body	Uplevel Radio																																																															
D	2008	STS	Body	Navigation Radio																																																															
D	2008	STS	Body	Rear Integration Module																																																															
D	2008	STS	Body	Remote Control Door Lock Receiver																																																															
D	2008	STS	Body	Right Rear Door Module																																																															
D	2008	STS	Body	Right Side Object Detection Module																																																															
D	2008	STS	Body	Steering Column Lock Module																																																															
D	2008	STS	Body	Supplemental Inflatable Restraint																																																															
D	2008	STS	Body	TV Antenna Module																																																															
D	2008	STS	Body	Vehicle Comm. Interface Module																																																															
D	2008	STS	Body	Veh Direction Alert Alarm Warn Mod																																																															
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																															
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																															
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																															
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																															
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																															
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																															
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																															
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																															
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																															
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																															
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																															
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																															
D	2009	CTS	Chassis	Electronic Brake Control Module																																																															
D	2009	CTS	Chassis	Electronic Suspension Control																																																															
D	2009	CTS	Chassis	Parking Brake Control Module																																																															
D	2009	CTS	Body	Body Control Module																																																															
D	2009	CTS	Body	Body Control Module (aux.)																																																															
D	2009	CTS	Body	Driver Door Switch																																																															
D	2009	CTS	Body	Headlamp Control Module																																																															
D	2009	CTS	Body	HVAC Control Module																																																															
D	2009	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																															
D	2009	CTS	Body	Instrument Panel Cluster (Other)																																																															
D	2009	CTS	Body	Memory Seat Module																																																															
D	2009	CTS	Body	Park Assist Module																																																															
D	2009	CTS	Body	Passenger Door Switch																																																															
D	2009	CTS	Body	Passenger Presence System																																																															
D	2009	CTS	Body	Pedestrian Impact Detection Module																																																															
D	2009	CTS	Body	Radio																																																															
D	2009	CTS	Body	Supplemental Inflatable Restraint																																																															
D	2009	CTS	Body	TV Antenna Module																																																															
D	2009	CTS	Body	Vehicle Comm. Interface Module																																																															
D	2009	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																															
D	2009	SLS	Powertrain	(T)2.8L V6 LP2 Transmission Control Module																																																															
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																															
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
D	2009	SLS	Chassis	Electronic Brake Control Module																																																												
D	2009	SLS	Chassis	Electronic Suspension Control																																																												
D	2009	SLS	Body	Amplifier (Bose)																																																												
D	2009	SLS	Body	Driver Door Module																																																												
D	2009	SLS	Body	Driver Door Switch																																																												
D	2009	SLS	Body	Driver Position Module																																																												
D	2009	SLS	Body	Headlamp Control Module																																																												
D	2009	SLS	Body	HVAC Control Module																																																												
D	2009	SLS	Body	Instrument Panel Cluster																																																												
D	2009	SLS	Body	Instrument Panel Module																																																												
D	2009	SLS	Body	Left Rear Door Module																																																												
D	2009	SLS	Body	Passenger Door Module																																																												
D	2009	SLS	Body	Radio																																																												
D	2009	SLS	Body	Rear HVAC/RSA																																																												
D	2009	SLS	Body	Rear Integration Module																																																												
D	2009	SLS	Body	Remote Control Door Lock Receiver																																																												
D	2009	SLS	Body	Right Rear Door Module																																																												
D	2009	SLS	Body	Supplemental Inflatable Restraint																																																												
D	2009	SLS	Body	TV Antenna Module																																																												
D	2009	SLS	Body	Vehicle Comm. Interface Module																																																												
D	2009	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																												
D	2009	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																												
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																												
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																												
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
D	2009	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																												
D	2009	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																												
D	2009	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																												
D	2009	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																												
D	2009	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																												
D	2009	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																												
D	2009	STS	Body	Amplifier (Bose)																																																												
D	2009	STS	Body	Digital Radio Receiver																																																												
D	2009	STS	Body	Distance Sensing Cruise Control																																																												
D	2009	STS	Body	Driver Door Module																																																												
D	2009	STS	Body	Driver Door Switch																																																												
D	2009	STS	Body	Driver Position Module																																																												
D	2009	STS	Body	Headlamp Control Module																																																												
D	2009	STS	Body	Head Up Display																																																												
D	2009	STS	Body	HVAC Control Module																																																												
D	2009	STS	Body	Instrument Panel Cluster																																																												
D	2009	STS	Body	Instrument Panel Module																																																												
D	2009	STS	Body	Left Rear Door Module																																																												
D	2009	STS	Body	Left Side Object Detection Module																																																												
D	2009	STS	Body	Passenger Door Module																																																												
D	2009	STS	Body	Uplevel Radio																																																												
D	2009	STS	Body	Navigation Radio																																																												
D	2009	STS	Body	Rear Integration Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2009	STS	Body	Remote Control Door Lock Receiver																																																												
D	2009	STS	Body	Right Rear Door Module																																																												
D	2009	STS	Body	Right Side Object Detection Module																																																												
D	2009	STS	Body	Steering Column Lock Module																																																												
D	2009	STS	Body	Supplemental Inflatable Restraint																																																												
D	2009	STS	Body	TV Antenna Module																																																												
D	2009	STS	Body	Vehicle Comm. Interface Module																																																												
D	2009	STS	Body	Veh Direction Alert Alarm Warn Mod																																																												
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																												
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																												
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																												
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																												
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Auto																																																												
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Manual																																																												
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transmission Control Module																																																												
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Fuel Pump Control Module																																																												
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transfer Case Control Module																																																												
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module Auto																																																												
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																												
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Fuel Pump Control Module																																																												
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																												
D	2010	CTS	Chassis	Electronic Brake Control Module																																																												
D	2010	CTS	Chassis	Electronic Suspension Control																																																												
D	2010	CTS	Chassis	Parking Brake Control Module																																																												
D	2010	CTS	Body	Body Control Module																																																												
D	2010	CTS	Body	Body Control Module (aux.)																																																												
D	2010	CTS	Body	Driver Door Switch																																																												
D	2010	CTS	Body	Headlamp Control Module																																																												
D	2010	CTS	Body	HVAC Control Module																																																												
D	2010	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																												
D	2010	CTS	Body	Instrument Panel Cluster (Other)																																																												
D	2010	CTS	Body	Liftgate Module																																																												
D	2010	CTS	Body	Memory Seat Module																																																												
D	2010	CTS	Body	Park Assist Module																																																												
D	2010	CTS	Body	Passenger Door Switch																																																												
D	2010	CTS	Body	Passenger Presence System																																																												
D	2010	CTS	Body	Pedestrian Impact Detection Module																																																												
D	2010	CTS	Body	Radio																																																												
D	2010	CTS	Body	Supplemental Inflatable Restraint																																																												
D	2010	CTS	Body	TV Antenna Module																																																												
D	2010	CTS	Body	Vehicle Comm. Interface Module																																																												
D	2010	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																												
D	2010	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																												
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
D	2010	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																												
D	2010	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																												
D	2010	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																												
D	2010	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																												
D	2010	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																												
D	2010	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2010	STS	Body	Amplifier (Bose)																																																														
D	2010	STS	Body	Digital Radio Receiver																																																														
D	2010	STS	Body	Distance Sensing Cruise Control																																																														
D	2010	STS	Body	Driver Door Module																																																														
D	2010	STS	Body	Driver Door Switch																																																														
D	2010	STS	Body	Driver Position Module																																																														
D	2010	STS	Body	Headlamp Control Module																																																														
D	2010	STS	Body	Head Up Display																																																														
D	2010	STS	Body	HVAC Control Module																																																														
D	2010	STS	Body	Instrument Panel Cluster																																																														
D	2010	STS	Body	Instrument Panel Module																																																														
D	2010	STS	Body	Left Rear Door Module																																																														
D	2010	STS	Body	Left Side Object Detection Module																																																														
D	2010	STS	Body	Passenger Door Module																																																														
D	2010	STS	Body	Uplevel Radio																																																														
D	2010	STS	Body	Navigation Radio																																																														
D	2010	STS	Body	Rear Integration Module																																																														
D	2010	STS	Body	Remote Control Door Lock Receiver																																																														
D	2010	STS	Body	Right Rear Door Module																																																														
D	2010	STS	Body	Right Side Object Detection Module																																																														
D	2010	STS	Body	Steering Column Lock Module																																																														
D	2010	STS	Body	Supplemental Inflatable Restraint																																																														
D	2010	STS	Body	TV Antenna Module																																																														
D	2010	STS	Body	Vehicle Comm. Interface Module																																																														
D	2010	STS	Body	Veh Direction Alert Alarm Warn Mod																																																														
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																														
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																														
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																														
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																														
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Auto																																																														
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Manual																																																														
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																														
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																														
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transfer Case Control Module																																																														
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																														
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																														
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Fuel Pump Control Module																																																														
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transfer Case Control Module																																																														
D	2011	CTS	Chassis	Electronic Brake Control Module																																																														
D	2011	CTS	Chassis	Electronic Suspension Control																																																														
D	2011	CTS	Chassis	Parking Brake Control Module																																																														
D	2011	CTS	Body	Body Control Module (6.2L V8 LSA)																																																														
D	2011	CTS	Body	Body Control Module (Other)																																																														
D	2011	CTS	Body	Body Control Module (aux.)																																																														
D	2011	CTS	Body	Driver Door Switch																																																														
D	2011	CTS	Body	Headlamp Control Module																																																														
D	2011	CTS	Body	HVAC Control Module																																																														
D	2011	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																														
D	2011	CTS	Body	Instrument Panel Cluster (Other)																																																														
D	2011	CTS	Body	Liftgate Module																																																														
D	2011	CTS	Body	Memory Seat Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2011	CTS	Body	Park Assist Module																																																														
D	2011	CTS	Body	Passenger Door Switch																																																															
D	2011	CTS	Body	Passenger Presence System																																																															
D	2011	CTS	Body	Pedestrian Impact Detection Module																																																															
D	2011	CTS	Body	Radio																																																															
D	2011	CTS	Body	Supplemental Inflatable Restraint																																																															
D	2011	CTS	Body	TV Antenna Module																																																															
D	2011	CTS	Body	Vehicle Comm. Interface Module																																																															
D	2011	STS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																															
D	2011	STS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																															
D	2011	STS	Chassis	Electronic Brake Control Module																																																															
D	2011	STS	Chassis	Electronic Suspension Control																																																															
D	2011	STS	Body	Amplifier (Bose)																																																															
D	2011	STS	Body	Digital Radio Receiver																																																															
D	2011	STS	Body	Distance Sensing Cruise Control																																																															
D	2011	STS	Body	Driver Door Module																																																															
D	2011	STS	Body	Driver Door Switch																																																															
D	2011	STS	Body	Driver Position Module																																																															
D	2011	STS	Body	Headlamp Control Module																																																															
D	2011	STS	Body	Head Up Display																																																															
D	2011	STS	Body	HVAC Control Module																																																															
D	2011	STS	Body	Instrument Panel Cluster																																																															
D	2011	STS	Body	Instrument Panel Module																																																															
D	2011	STS	Body	Left Rear Door Module																																																															
D	2011	STS	Body	Left Side Object Detection Module																																																															
D	2011	STS	Body	Passenger Door Module																																																															
D	2011	STS	Body	Uplevel Radio																																																															
D	2011	STS	Body	Navigation Radio																																																															
D	2011	STS	Body	Rear Integration Module																																																															
D	2011	STS	Body	Remote Control Door Lock Receiver																																																															
D	2011	STS	Body	Right Rear Door Module																																																															
D	2011	STS	Body	Right Side Object Detection Module																																																															
D	2011	STS	Body	Supplemental Inflatable Restraint																																																															
D	2011	STS	Body	TV Antenna Module																																																															
D	2011	STS	Body	Vehicle Comm. Interface Module																																																															
D	2011	STS	Body	Veh Direction Alert Alarm Warn Mod																																																															
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																															
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																															
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																															
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																															
D	2012	P Type Engine	Chassis	Electronic Brake Control Module																																																															
D	2012	P Type Engine	Chassis	Electronic Suspension Control																																																															
D	2012	P Type Engine	Chassis	Parking Brake Control Module																																																															
D	2012	P Type Engine	Body	Body Control Module																																																															
D	2012	P Type Engine	Body	Body Control Module (aux.)																																																															
D	2012	P Type Engine	Body	Driver Door Switch																																																															
D	2012	P Type Engine	Body	Headlamp Control Module																																																															
D	2012	P Type Engine	Body	HVAC Control Module																																																															
D	2012	P Type Engine	Body	Instrument Panel Cluster																																																															
D	2012	P Type Engine	Body	Left Side Object Detection Module																																																															
D	2012	P Type Engine	Body	Liftgate Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2012	P Type Engine	Body	Memory Seat Module																																																															
D	2012	P Type Engine	Body	Park Assist Module																																																															
D	2012	P Type Engine	Body	Passenger Door Switch																																																															
D	2012	P Type Engine	Body	Passenger Presence System																																																															
D	2012	P Type Engine	Body	Pedestrian Impact Detection Module																																																															
D	2012	P Type Engine	Body	Radio																																																															
D	2012	P Type Engine	Body	Right Side Object Detection Module																																																															
D	2012	P Type Engine	Body	Supplemental Inflatable Restraint																																																															
D	2012	P Type Engine	Body	TV Antenna Module																																																															
D	2012	P Type Engine	Body	Vehicle Comm. Interface Module																																																															
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto																																																															
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual																																																															
D	2012	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																															
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																															
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																															
D	2012	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																															
D	2012	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																															
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																															
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																															
D	2012	Other	Chassis	Electronic Brake Control Module																																																															
D	2012	Other	Chassis	Electronic Suspension Control																																																															
D	2012	Other	Chassis	Parking Brake Control Module																																																															
D	2012	Other	Body	Body Control Module																																																															
D	2012	Other	Body	Body Control Module (aux.)																																																															
D	2012	Other	Body	Driver Door Switch																																																															
D	2012	Other	Body	Headlamp Control Module																																																															
D	2012	Other	Body	HVAC Control Module																																																															
D	2012	Other	Body	Instrument Panel Cluster																																																															
D	2012	Other	Body	Left Side Object Detection Module																																																															
D	2012	Other	Body	Liftgate Module																																																															
D	2012	Other	Body	Memory Seat Module																																																															
D	2012	Other	Body	Park Assist Module																																																															
D	2012	Other	Body	Passenger Door Switch																																																															
D	2012	Other	Body	Passenger Presence System																																																															
D	2012	Other	Body	Pedestrian Impact Detection Module																																																															
D	2012	Other	Body	Radio																																																															
D	2012	Other	Body	Right Side Object Detection Module																																																															
D	2012	Other	Body	Supplemental Inflatable Restraint																																																															
D	2012	Other	Body	TV Antenna Module																																																															
D	2012	Other	Body	Vehicle Comm. Interface Module																																																															
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																															
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																															
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																															
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																															
D	2013	P Type Engine	Chassis	Electronic Brake Control Module																																																															
D	2013	P Type Engine	Chassis	Electronic Suspension Control																																																															
D	2013	P Type Engine	Chassis	Parking Brake Control Module																																																															
D	2013	P Type Engine	Body	Body Control Module																																																															
D	2013	P Type Engine	Body	Body Control Module (aux.)																																																															
D	2013	P Type Engine	Body	Driver Door Switch																																																															
D	2013	P Type Engine	Body	Headlamp Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2013	P Type Engine	Body	HVAC Control Module																																																													
D	2013	P Type Engine	Body	Instrument Panel Cluster																																																													
D	2013	P Type Engine	Body	Left Side Object Detection Module																																																												
D	2013	P Type Engine	Body	Liftgate Module																																																												
D	2013	P Type Engine	Body	Memory Seat Module																																																												
D	2013	P Type Engine	Body	Park Assist Module																																																												
D	2013	P Type Engine	Body	Passenger Door Switch																																																												
D	2013	P Type Engine	Body	Passenger Presence System																																																												
D	2013	P Type Engine	Body	Pedestrian Impact Detection Module																																																												
D	2013	P Type Engine	Body	Radio																																																												
D	2013	P Type Engine	Body	Right Side Object Detection Module																																																												
D	2013	P Type Engine	Body	Supplemental Inflatable Restraint																																																												
D	2013	P Type Engine	Body	TV Antenna Module																																																												
D	2013	P Type Engine	Body	Vehicle Comm. Interface Module																																																												
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto																																																												
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual																																																												
D	2013	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																												
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																												
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																												
D	2013	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																												
D	2013	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																												
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																												
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																												
D	2013	Other	Chassis	Electronic Brake Control Module																																																												
D	2013	Other	Chassis	Electronic Suspension Control																																																												
D	2013	Other	Chassis	Parking Brake Control Module																																																												
D	2013	Other	Body	Body Control Module																																																												
D	2013	Other	Body	Body Control Module (aux.)																																																												
D	2013	Other	Body	Driver Door Switch																																																												
D	2013	Other	Body	Headlamp Control Module																																																												
D	2013	Other	Body	HVAC Control Module																																																												
D	2013	Other	Body	Instrument Panel Cluster																																																												
D	2013	Other	Body	Left Side Object Detection Module																																																												
D	2013	Other	Body	Liftgate Module																																																												
D	2013	Other	Body	Memory Seat Module																																																												
D	2013	Other	Body	Park Assist Module																																																												
D	2013	Other	Body	Passenger Door Switch																																																												
D	2013	Other	Body	Passenger Presence System																																																												
D	2013	Other	Body	Pedestrian Impact Detection Module																																																												
D	2013	Other	Body	Radio																																																												
D	2013	Other	Body	Right Side Object Detection Module																																																												
D	2013	Other	Body	Supplemental Inflatable Restraint																																																												
D	2013	Other	Body	TV Antenna Module																																																												
D	2013	Other	Body	Vehicle Comm. Interface Module																																																												
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
D	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
D	2014	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																											
D	2014	CTS	Powertrain	Chassis Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2014	CTS	Powertrain	Transfer Case Control Module																																																														
D	2014	CTS	Chassis	Electronic Brake Control Module																																																														
D	2014	CTS	Chassis	Parking Brake Control Module																																																													
D	2014	CTS	Chassis	Suspension Control Module																																																													
D	2014	CTS	Body	Body Control Module Coupe																																																													
D	2014	CTS	Body	Body Control Module Station Wagon																																																													
D	2014	CTS	Body	Auxiliary Body Control Module																																																													
D	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
D	2014	CTS	Body	Passenger Presence Module																																																													
D	2014	CTS	Body	Pedestrian Impact Detection Module																																																													
D	2014	CTS	Body	Instrument Cluster																																																													
D	2014	CTS	Body	Headlamp Control Module																																																													
D	2014	CTS	Body	Radio																																																													
D	2014	CTS	Body	Amplifier																																																													
D	2014	CTS	Body	Television Antenna Module																																																													
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																													
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																													
D	2014	CTS	Body	HVAC Control Module																																																													
D	2014	CTS	Body	Driver Door Switch Panel Control Module																																																													
D	2014	CTS	Body	Passenger Door Switch Panel Control Module																																																													
D	2014	CTS	Body	Liftgate Control Module																																																													
D	2014	CTS	Body	Seat Memory Control Module																																																													
D	2014	CTS	Body	Right Side Object Detection Control Module																																																													
D	2014	CTS	Body	Left Side Object Detection Control Module																																																													
D	2014	CTS	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																													
D	2014	CTS	Body	Remote Control Keyless Type Standard Range (ATG)																																																													
D	2014	CTS	Body	Parking Assist Control Module																																																													
D	2014	CTS	Body	Theft Deterrent Module																																																													
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																													
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																													
D	2015	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																													
D	2015	CTS	Powertrain	Chassis Control Module																																																													
D	2015	CTS	Powertrain	Transfer Case Control Module																																																													
D	2015	CTS	Chassis	Electronic Brake Control Module																																																													
D	2015	CTS	Chassis	Parking Brake Control Module																																																													
D	2015	CTS	Chassis	Suspension Control Module																																																													
D	2015	CTS	Body	Body Control Module Coupe																																																													
D	2015	CTS	Body	Body Control Module Station Wagon																																																													
D	2015	CTS	Body	Auxiliary Body Control Module																																																													
D	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
D	2015	CTS	Body	Passenger Presence Module																																																													
D	2015	CTS	Body	Pedestrian Impact Detection Module																																																													
D	2015	CTS	Body	Instrument Cluster																																																													
D	2015	CTS	Body	Headlamp Control Module																																																													
D	2015	CTS	Body	Radio																																																												
D	2015	CTS	Body	Amplifier																																																												
D	2015	CTS	Body	Television Antenna Module																																																													
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 9																																																													
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																													
D	2015	CTS	Body	HVAC Control Module																																																													
D	2015	CTS	Body	Driver Door Switch Panel Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2015	CTS	Body	Passenger Door Switch Panel Control Module																																																														
D	2015	CTS	Body	Liftgate Control Module																																																															
D	2015	CTS	Body	Seat Memory Control Module																																																															
D	2015	CTS	Body	Right Side Object Detection Control Module																																																															
D	2015	CTS	Body	Left Side Object Detection Control Module																																																															
D	2015	CTS	Body	Remote Control Door Lock Receiver																																																															
D	2015	CTS	Body	Parking Assist Control Module																																																															
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																															
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																															
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																															
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																															
K	2004	(KD)Deville	Body	Amplifier (Delco)																																																															
K	2004	(KD)Deville	Body	CD Changer																																																															
K	2004	(KD)Deville	Body	Dash Integration Module																																																															
K	2004	(KD)Deville	Body	Digital Radio Receiver																																																															
K	2004	(KD)Deville	Body	Driver Door Switch																																																															
K	2004	(KD)Deville	Body	Driver Door Module																																																															
K	2004	(KD)Deville	Body	Passenger Door Module																																																															
K	2004	(KD)Deville	Body	Left Rear Door Module																																																															
K	2004	(KD)Deville	Body	Right Rear Door Module																																																															
K	2004	(KD)Deville	Body	Instrument Panel Cluster																																																															
K	2004	(KD)Deville	Body	Instrument Panel Module																																																															
K	2004	(KD)Deville	Body	Memory Seat Module																																																															
K	2004	(KD)Deville	Body	Navigation Radio																																																															
K	2004	(KD)Deville	Body	Radio																																																															
K	2004	(KD)Deville	Body	Rear Climate Control Panel																																																															
K	2004	(KD)Deville	Body	Rear Integration Module																																																															
K	2004	(KD)Deville	Body	Remote Function Actuation																																																															
K	2004	(KD)Deville	Body	Supplemental Inflatable Restraint																																																															
K	2004	(KD)Deville	Body	Tilt Telescope Module																																																															
K	2004	(KD)Deville	Body	Vehicle Theft Deterrent																																																															
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																															
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																															
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																															
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																															
K	2004	(KE)DHS	Body	Amplifier (Bose)																																																															
K	2004	(KE)DHS	Body	CD Changer																																																															
K	2004	(KE)DHS	Body	Dash Integration Module																																																															
K	2004	(KE)DHS	Body	Digital Radio Receiver																																																															
K	2004	(KE)DHS	Body	Driver Door Switch																																																															
K	2004	(KE)DHS	Body	Driver Door Module																																																															
K	2004	(KE)DHS	Body	Passenger Door Module																																																															
K	2004	(KE)DHS	Body	Left Rear Door Module																																																															
K	2004	(KE)DHS	Body	Right Rear Door Module																																																															
K	2004	(KE)DHS	Body	Instrument Panel Cluster																																																															
K	2004	(KE)DHS	Body	Instrument Panel Module																																																															
K	2004	(KE)DHS	Body	Memory Seat Module																																																															
K	2004	(KE)DHS	Body	Navigation Radio																																																															
K	2004	(KE)DHS	Body	Radio																																																															
K	2004	(KE)DHS	Body	Rear Climate Control Panel																																																															
K	2004	(KE)DHS	Body	Rear Integration Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2004	(KE)DHS	Body	Remote Function Actuation																																																												
K	2004	(KE)DHS	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KE)DHS	Body	Tilt Telescope Module																																																												
K	2004	(KE)DHS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																												
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																												
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																												
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																												
K	2004	(KF)DTS	Body	Amplifier (Bose)																																																												
K	2004	(KF)DTS	Body	CD Changer																																																												
K	2004	(KF)DTS	Body	Dash Integration Module																																																												
K	2004	(KF)DTS	Body	Digital Radio Receiver																																																												
K	2004	(KF)DTS	Body	Driver Door Switch																																																												
K	2004	(KF)DTS	Body	Driver Door Module																																																												
K	2004	(KF)DTS	Body	Passenger Door Module																																																												
K	2004	(KF)DTS	Body	Left Rear Door Module																																																												
K	2004	(KF)DTS	Body	Right Rear Door Module																																																												
K	2004	(KF)DTS	Body	Instrument Panel Cluster																																																												
K	2004	(KF)DTS	Body	Instrument Panel Module																																																												
K	2004	(KF)DTS	Body	Memory Seat Module																																																												
K	2004	(KF)DTS	Body	Navigation Radio																																																												
K	2004	(KF)DTS	Body	Radio																																																												
K	2004	(KF)DTS	Body	Rear Climate Control Panel																																																												
K	2004	(KF)DTS	Body	Rear Integration Module																																																												
K	2004	(KF)DTS	Body	Remote Function Actuation																																																												
K	2004	(KF)DTS	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KF)DTS	Body	Tilt Telescope Module																																																												
K	2004	(KF)DTS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																												
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																												
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																												
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																												
K	2004	(KS)Seville SLS	Body	Amplifier (Bose)																																																												
K	2004	(KS)Seville SLS	Body	Amplifier (Delco)																																																												
K	2004	(KS)Seville SLS	Body	CD Changer																																																												
K	2004	(KS)Seville SLS	Body	Dash Integration Module																																																												
K	2004	(KS)Seville SLS	Body	Digital Radio Receiver																																																												
K	2004	(KS)Seville SLS	Body	Driver Door Module																																																												
K	2004	(KS)Seville SLS	Body	Instrument Panel Cluster																																																												
K	2004	(KS)Seville SLS	Body	Instrument Panel Module																																																												
K	2004	(KS)Seville SLS	Body	Memory Seat Module																																																												
K	2004	(KS)Seville SLS	Body	Navigation Radio																																																												
K	2004	(KS)Seville SLS	Body	Radio																																																												
K	2004	(KS)Seville SLS	Body	Rear Integration Module																																																												
K	2004	(KS)Seville SLS	Body	Remote Function Actuation																																																												
K	2004	(KS)Seville SLS	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KS)Seville SLS	Body	Tilt Telescope Module																																																												
K	2004	(KS)Seville SLS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																												
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																												
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																												
K	2004	(KY)Seville STS	Body	Amplifier (Bose)																																																													
K	2004	(KY)Seville STS	Body	Amplifier (Delco)																																																													
K	2004	(KY)Seville STS	Body	CD Changer																																																													
K	2004	(KY)Seville STS	Body	Dash Integration Module																																																													
K	2004	(KY)Seville STS	Body	Digital Radio Receiver																																																													
K	2004	(KY)Seville STS	Body	Driver Door Module																																																													
K	2004	(KY)Seville STS	Body	Instrument Panel Cluster																																																													
K	2004	(KY)Seville STS	Body	Instrument Panel Module																																																													
K	2004	(KY)Seville STS	Body	Memory Seat Module																																																													
K	2004	(KY)Seville STS	Body	Navigation Radio																																																													
K	2004	(KY)Seville STS	Body	Radio																																																													
K	2004	(KY)Seville STS	Body	Rear Integration Module																																																													
K	2004	(KY)Seville STS	Body	Remote Function Actuation																																																													
K	2004	(KY)Seville STS	Body	Supplemental Inflatable Restraint																																																													
K	2004	(KY)Seville STS	Body	Tilt Telescope Module																																																													
K	2004	(KY)Seville STS	Body	Vehicle Theft Deterrent																																																													
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																													
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																													
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																													
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																													
K	2005	(KD)Deville	Body	Amplifier (Delco)																																																													
K	2005	(KD)Deville	Body	CD Changer																																																													
K	2005	(KD)Deville	Body	Dash Integration Module																																																													
K	2005	(KD)Deville	Body	Digital Radio Receiver																																																													
K	2005	(KD)Deville	Body	Driver Door Switch																																																													
K	2005	(KD)Deville	Body	Driver Door Module																																																													
K	2005	(KD)Deville	Body	Passenger Door Module																																																													
K	2005	(KD)Deville	Body	Left Rear Door Module																																																													
K	2005	(KD)Deville	Body	Right Rear Door Module																																																													
K	2005	(KD)Deville	Body	Instrument Panel Cluster																																																													
K	2005	(KD)Deville	Body	Instrument Panel Module																																																													
K	2005	(KD)Deville	Body	Memory Seat Module																																																													
K	2005	(KD)Deville	Body	Navigation Radio																																																													
K	2005	(KD)Deville	Body	Radio																																																													
K	2005	(KD)Deville	Body	Rear Climate Control Panel																																																													
K	2005	(KD)Deville	Body	Rear Integration Module																																																													
K	2005	(KD)Deville	Body	Remote Function Actuation																																																													
K	2005	(KD)Deville	Body	Supplemental Inflatable Restraint																																																													
K	2005	(KD)Deville	Body	Tilt Telescope Module																																																													
K	2005	(KD)Deville	Body	Vehicle Theft Deterrent																																																													
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																													
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																													
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																													
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																													
K	2005	(KE)DHS	Body	Amplifier (Bose)																																																													
K	2005	(KE)DHS	Body	CD Changer																																																													
K	2005	(KE)DHS	Body	Dash Integration Module																																																													
K	2005	(KE)DHS	Body	Digital Radio Receiver																																																													
K	2005	(KE)DHS	Body	Driver Door Switch																																																													
K	2005	(KE)DHS	Body	Driver Door Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2005	(KE)DHS	Body	Passenger Door Module																																																															
K	2005	(KE)DHS	Body	Left Rear Door Module																																																															
K	2005	(KE)DHS	Body	Right Rear Door Module																																																															
K	2005	(KE)DHS	Body	Instrument Panel Cluster																																																															
K	2005	(KE)DHS	Body	Instrument Panel Module																																																															
K	2005	(KE)DHS	Body	Memory Seat Module																																																															
K	2005	(KE)DHS	Body	Navigation Radio																																																															
K	2005	(KE)DHS	Body	Radio																																																															
K	2005	(KE)DHS	Body	Rear Climate Control Panel																																																															
K	2005	(KE)DHS	Body	Rear Integration Module																																																															
K	2005	(KE)DHS	Body	Remote Function Actuation																																																															
K	2005	(KE)DHS	Body	Supplemental Inflatable Restraint																																																															
K	2005	(KE)DHS	Body	Tilt Telescope Module																																																															
K	2005	(KE)DHS	Body	Vehicle Theft Deterrent																																																															
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																															
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																															
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																															
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																															
K	2005	(KF)DTS	Body	Amplifier (Bose)																																																															
K	2005	(KF)DTS	Body	CD Changer																																																															
K	2005	(KF)DTS	Body	Dash Integration Module																																																															
K	2005	(KF)DTS	Body	Digital Radio Receiver																																																															
K	2005	(KF)DTS	Body	Driver Door Switch																																																															
K	2005	(KF)DTS	Body	Driver Door Module																																																															
K	2005	(KF)DTS	Body	Passenger Door Module																																																															
K	2005	(KF)DTS	Body	Left Rear Door Module																																																															
K	2005	(KF)DTS	Body	Right Rear Door Module																																																															
K	2005	(KF)DTS	Body	Instrument Panel Cluster																																																															
K	2005	(KF)DTS	Body	Instrument Panel Module																																																															
K	2005	(KF)DTS	Body	Memory Seat Module																																																															
K	2005	(KF)DTS	Body	Navigation Radio																																																															
K	2005	(KF)DTS	Body	Radio																																																															
K	2005	(KF)DTS	Body	Rear Climate Control Panel																																																															
K	2005	(KF)DTS	Body	Rear Integration Module																																																															
K	2005	(KF)DTS	Body	Remote Function Actuation																																																															
K	2005	(KF)DTS	Body	Supplemental Inflatable Restraint																																																														
K	2005	(KF)DTS	Body	Tilt Telescope Module																																																															
K	2005	(KF)DTS	Body	Vehicle Theft Deterrent																																																															
K	2006	ALL	Powertrain	Engine Control Module																																																															
K	2006	ALL	Powertrain	Automatic Transaxle																																																															
K	2006	ALL	Chassis	Antilock Brake System																																																															
K	2006	ALL	Body	Amplifier (Bose)																																																															
K	2006	ALL	Body	Aux. HVAC Control Module																																																															
K	2006	ALL	Body	Body Control Module																																																															
K	2006	ALL	Body	Digital Radio Receiver																																																															
K	2006	ALL	Body	Distance Sensing Cruise Control																																																															
K	2006	ALL	Body	Driver Door Switch																																																															
K	2006	ALL	Body	Driver Position Module																																																															
K	2006	ALL	Body	HVAC Control Module																																																															
K	2006	ALL	Body	Instrument Panel Cluster																																																															
K	2006	ALL	Body	Park Assist Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2006	ALL	Body	Passenger Door Switch																																																														
K	2006	ALL	Body	Passenger Presence System																																																															
K	2006	ALL	Body	Radio																																																														
K	2006	ALL	Body	Rear Heated Seat Module																																																														
K	2006	ALL	Body	Remote Control Door Lock Receiver																																																														
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2006	ALL	Body	Theft Deterrent Module																																																														
K	2006	ALL	Body	TV Antenna Module																																																														
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																														
K	2007	ALL	Powertrain	Engine Control Module																																																															
K	2007	ALL	Powertrain	Transmission Control Module																																																															
K	2007	ALL	Chassis	Electronic Brake Control Module																																																															
K	2007	ALL	Body	Amplifier (Bose)																																																															
K	2007	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																															
K	2007	ALL	Body	Body Control Module																																																															
K	2007	ALL	Body	Digital Radio Receiver																																																															
K	2007	ALL	Body	Distance Sensing Cruise Control																																																															
K	2007	ALL	Body	Driver Door Switch																																																															
K	2007	ALL	Body	Driver Position Module																																																															
K	2007	ALL	Body	CJ2 Dual Zone HVAC Auto																																																															
K	2007	ALL	Body	CJ4 Tri Zone HVAC Auto																																																															
K	2007	ALL	Body	Inside Rear View Mirror Module																																																															
K	2007	ALL	Body	Instrument Panel Cluster																																																															
K	2007	ALL	Body	Park Assist Module																																																															
K	2007	ALL	Body	Passenger Door Switch																																																															
K	2007	ALL	Body	Passenger Presence System																																																															
K	2007	ALL	Body	Radio																																																															
K	2007	ALL	Body	Rear Heated Seat Module																																																															
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																															
K	2007	ALL	Body	Theft Deterrent Module																																																															
K	2007	ALL	Body	TV Antenna Module																																																															
K	2007	ALL	Body	Vehicle Comm. Interface Module																																																															
K	2008	ALL	Powertrain	Engine Control Module																																																															
K	2008	ALL	Powertrain	Transmission Control Module																																																															
K	2008	ALL	Chassis	Electronic Brake Control Module																																																															
K	2008	ALL	Body	Amplifier (Bose)																																																															
K	2008	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																															
K	2008	ALL	Body	Body Control Module																																																															
K	2008	ALL	Body	Digital Radio Receiver																																																															
K	2008	ALL	Body	Distance Sensing Cruise Control																																																															
K	2008	ALL	Body	Driver Door Switch																																																															
K	2008	ALL	Body	Driver Position Module																																																															
K	2008	ALL	Body	CJ2 Dual Zone HVAC Auto																																																															
K	2008	ALL	Body	CJ4 Tri Zone HVAC Auto																																																															
K	2008	ALL	Body	Inside Rear View Mirror Module																																																															
K	2008	ALL	Body	Instrument Panel Cluster																																																															
K	2008	ALL	Body	Left Side Object Detection Module																																																															
K	2008	ALL	Body	Park Assist Module																																																															
K	2008	ALL	Body	Passenger Door Switch																																																															
K	2008	ALL	Body	Passenger Presence System																																																															
K	2008	ALL	Body	Radio																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2008	ALL	Body	Rear Heated Seat Module																																																															
K	2008	ALL	Body	Right Side Object Detection Module																																																															
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																															
K	2008	ALL	Body	Theft Deterrent Module																																																															
K	2008	ALL	Body	TV Antenna Module																																																															
K	2008	ALL	Body	Vehicle Comm. Interface Module																																																															
K	2008	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																															
K	2009	ALL	Powertrain	Engine Control Module																																																															
K	2009	ALL	Powertrain	Transmission Control Module																																																															
K	2009	ALL	Chassis	Electronic Brake Control Module																																																															
K	2009	ALL	Body	Amplifier (Bose)																																																															
K	2009	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																															
K	2009	ALL	Body	Body Control Module																																																															
K	2009	ALL	Body	Digital Radio Receiver																																																															
K	2009	ALL	Body	Distance Sensing Cruise Control																																																															
K	2009	ALL	Body	Driver Door Switch																																																															
K	2009	ALL	Body	Driver Position Module																																																															
K	2009	ALL	Body	CJ2 Dual Zone HVAC Auto																																																															
K	2009	ALL	Body	CJ4 Tri Zone HVAC Auto																																																															
K	2009	ALL	Body	Inside Rear View Mirror Module																																																															
K	2009	ALL	Body	Instrument Panel Cluster																																																															
K	2009	ALL	Body	Left Side Object Detection Module																																																															
K	2009	ALL	Body	Park Assist Module																																																															
K	2009	ALL	Body	Passenger Door Switch																																																															
K	2009	ALL	Body	Passenger Presence System																																																															
K	2009	ALL	Body	Radio																																																															
K	2009	ALL	Body	Rear Heated Seat Module																																																															
K	2009	ALL	Body	Right Side Object Detection Module																																																															
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
K	2009	ALL	Body	Theft Deterrent Module																																																															
K	2009	ALL	Body	TV Antenna Module																																																															
K	2009	ALL	Body	Vehicle Comm. Interface Module																																																															
K	2009	ALL	Body	Vehicle Comm. Interface Module																																																															
K	2009	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																															
K	2010	ALL	Powertrain	Engine Control Module																																																															
K	2010	ALL	Powertrain	Transmission Control Module																																																															
K	2010	ALL	Chassis	Electronic Brake Control Module																																																															
K	2010	ALL	Body	Amplifier (Bose)																																																															
K	2010	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																															
K	2010	ALL	Body	Body Control Module																																																															
K	2010	ALL	Body	Digital Radio Receiver																																																															
K	2010	ALL	Body	Distance Sensing Cruise Control																																																															
K	2010	ALL	Body	Driver Door Switch																																																															
K	2010	ALL	Body	Driver Position Module																																																															
K	2010	ALL	Body	CJ2 Dual Zone HVAC Auto																																																															
K	2010	ALL	Body	CJ4 Tri Zone HVAC Auto																																																															
K	2010	ALL	Body	Inside Rear View Mirror Module																																																															
K	2010	ALL	Body	Instrument Panel Cluster																																																															
K	2010	ALL	Body	Left Side Object Detection Module																																																															
K	2010	ALL	Body	Park Assist Module																																																															
K	2010	ALL	Body	Passenger Door Switch																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2010	ALL	Body	Passenger Presence System																																																													
K	2010	ALL	Body	Radio																																																													
K	2010	ALL	Body	Rear Heated Seat Module																																																													
K	2010	ALL	Body	Right Side Object Detection Module																																																													
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																													
K	2010	ALL	Body	Theft Deterrent Module																																																													
K	2010	ALL	Body	TV Antenna Module																																																													
K	2010	ALL	Body	Vehicle Comm. Interface Module																																																													
K	2010	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																													
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Engine Control Module																																																													
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Transmission Control Module																																																													
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Engine Control Module																																																													
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Transmission Control Module																																																													
K	2011	ALL	Chassis	Electronic Brake Control Module																																																														
K	2011	ALL	Body	Amplifier (Bose)																																																														
K	2011	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																														
K	2011	ALL	Body	Body Control Module																																																														
K	2011	ALL	Body	Digital Radio Receiver																																																														
K	2011	ALL	Body	Distance Sensing Cruise Control																																																														
K	2011	ALL	Body	Driver Door Switch																																																														
K	2011	ALL	Body	Driver Position Module																																																														
K	2011	ALL	Body	CJ2 Dual Zone HVAC Auto																																																														
K	2011	ALL	Body	CJ4 Tri Zone HVAC Auto																																																														
K	2011	ALL	Body	Inside Rear View Mirror Module																																																														
K	2011	ALL	Body	Instrument Panel Cluster																																																														
K	2011	ALL	Body	Left Side Object Detection Module																																																														
K	2011	ALL	Body	Park Assist Module																																																														
K	2011	ALL	Body	Passenger Door Switch																																																														
K	2011	ALL	Body	Passenger Presence System																																																														
K	2011	ALL	Body	Radio																																																														
K	2011	ALL	Body	Rear Heated Seat Module																																																														
K	2011	ALL	Body	Right Side Object Detection Module																																																														
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2011	ALL	Body	Theft Deterrent Module																																																														
K	2011	ALL	Body	TV Antenna Module																																																														
K	2011	ALL	Body	Vehicle Comm. Interface Module																																																														
K	2011	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																														
K	2016	CT6	Powertrain	(X) 2.0L LTG Engine Control Module																																																														
K	2016	CT6	Powertrain	(X) 2.0L LTG Transmission Control Module																																																														
K	2016	CT6	Powertrain	(6) 3.0L LGW Engine Control Module																																																														
K	2016	CT6	Powertrain	(6) 3.0L LGW Transmission Control Module																																																														
K	2016	CT6	Powertrain	(S) 3.6L LGX Engine Control Module																																																														
K	2016	CT6	Powertrain	(S) 3.6L LGX Transmission Control Module																																																														
K	2016	CT6	Powertrain	Transfer Case Control Module																																																														
K	2016	CT6	Chassis	Electronic Brake Control Module																																																														
K	2016	CT6	Chassis	Brake Booster Control Module																																																														
K	2016	CT6	Chassis	Power Steering Control Module																																																														
K	2016	CT6	Chassis	Rear Wheel Steering Control Module																																																														
K	2016	CT6	Chassis	Suspension Control Module																																																														
K	2016	CT6	Body	Body Control Module																																																														
K	2016	CT6	Body	Serial Data Gateway Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2016	CT6	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
K	2016	CT6	Body	Passenger Presence Module																																																														
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Left																																																													
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Right																																																													
K	2016	CT6	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																													
K	2016	CT6	Body	Instrument Cluster Full Screen Display (UDV)																																																													
K	2016	CT6	Body	Radio Controls																																																													
K	2016	CT6	Body	HVAC Controls																																																													
K	2016	CT6	Body	Active Safety Control Module																																																													
K	2016	CT6	Body	Video Processing Control Module																																																													
K	2016	CT6	Body	Headlamp Control Module																																																													
K	2016	CT6	Body	Trailer Interface Control Module																																																													
K	2016	CT6	Body	Radio																																																													
K	2016	CT6	Body	Amplifier																																																												
K	2016	CT6	Body	Infotainment Control Touchpad																																																												
K	2016	CT6	Body	Human Machine Interface Control Module																																																												
K	2016	CT6	Body	Navigation Control Module																																																												
K	2016	CT6	Body	Telematics Communication Interface Control Module																																																												
K	2016	CT6	Body	HVAC Control Module																																																												
K	2016	CT6	Body	Liftgate Control Module																																																												
K	2016	CT6	Body	Seat Memory Control Module - Passenger																																																												
K	2016	CT6	Body	Seat Memory Control Module - Left Rear																																																												
K	2016	CT6	Body	Seat Memory Control Module - Driver																																																												
K	2016	CT6	Body	Seat Memory Control Module - Right Rear																																																												
K	2016	CT6	Body	Keyless Entry Control Module																																																												
K	2016	CT6	Body	Left Side Object Detection Control Module																																																												
K	2016	CT6	Body	Parking Assist Control Module																																																												
K	2016	CT6	Body	Frontview Camera Module																																																												
K	2016	CT6	Body	Long Range Radar Sensor Module																																																												
K	2016	CT6	Body	Left Front Short Range Radar Sensor Module																																																												
K	2016	CT6	Body	Right Front Short Range Radar Sensor Module																																																												
K	2016	CT6	Body	Rear Short Range Radar Sensor Module																																																												
K	2016	CT6	Body	Night Vision Camera Control Module																																																												
R	2014	ELR	Powertrain	Engine Control Module																																																												
R	2014	ELR	Powertrain	Trasmission Control Module																																																												
R	2014	ELR	Powertrain	Chassis Control Module																																																												
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module																																																												
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module 2	V																																																											
R	2014	ELR	Powertrain	Drive Motor Control Module 1																																																												
R	2014	ELR	Powertrain	Drive Motor Control Module 2																																																												
R	2014	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2014	ELR	Chassis	Electronic Brake Control Module		V	V																																																										
R	2014	ELR	Chassis	Distance Sensing Cruise Control Module																																																												
R	2014	ELR	Chassis	Parking Brake Control Module																																																												
R	2014	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																												
R	2014	ELR	Chassis	Power Steering Control Module																																																												
R	2014	ELR	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2014	ELR	Chassis	Suspension Control Module																																																												
R	2014	ELR	Body	Body Control Module																																																												
R	2014	ELR	Body	Pedestrian Impact Detection Module																																																												
R	2014	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2014	ELR	Body	Passenger Presence Module																																																															
R	2014	ELR	Body	Instrument Cluster																																																															
R	2014	ELR	Body	Radio/HVAC Control																																																															
R	2014	ELR	Body	Radio																																																															
R	2014	ELR	Body	Amplifier																																																															
R	2014	ELR	Body	Human Machine Interface Control Module																																																															
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 9																																																															
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 10																																																															
R	2014	ELR	Body	HVAC Control Module																																																															
R	2014	ELR	Body	Electric A/C Compressor Control Module																																																															
R	2014	ELR	Body	Coolant Heater Control Module																																																															
R	2014	ELR	Body	Seat Memory Control Module - Driver																																																															
R	2014	ELR	Body	Keyless Entry Control Module																																																															
R	2014	ELR	Body	Right Side Object Detection Control Module																																																															
R	2014	ELR	Body	Left Side Object Detection Control Module																																																															
R	2014	ELR	Body	Parking Assist Control Module																																																															
R	2014	ELR	Body	Frontview Camera Module																																																															
R	2014	ELR	Body	Steering Column Lock Control Module																																																															
R	2014	ELR	Body	Battery Charger Control Module																																																															
R	2014	ELR	Body	Battery Energy Control Module				V	V	V	V																																																							
R	2015	ELR	Powertrain	Engine Control Module																																																															
R	2015	ELR	Powertrain	Trasmission Control Module																																																															
R	2015	ELR	Powertrain	Chassis Control Module																																																															
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module																																																															
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module 2	V																																																														
R	2015	ELR	Powertrain	Drive Motor Control Module 1																																																															
R	2015	ELR	Powertrain	Drive Motor Control Module 2																																																															
R	2015	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																															
R	2015	ELR	Chassis	Electronic Brake Control Module		V	V																																																												
R	2015	ELR	Chassis	Distance Sensing Cruise Control Module																																																															
R	2015	ELR	Chassis	Parking Brake Control Module																																																															
R	2015	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																															
R	2015	ELR	Chassis	Power Steering Control Module																																																															
R	2015	ELR	Chassis	Steering Wheel Angle Sensor Module																																																															
R	2015	ELR	Chassis	Suspension Control Module																																																															
R	2015	ELR	Body	Body Control Module																																																															
R	2015	ELR	Body	Pedestrian Impact Detection Module																																																															
R	2015	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
R	2015	ELR	Body	Passenger Presence Module																																																															
R	2015	ELR	Body	Instrument Cluster																																																															
R	2015	ELR	Body	Radio/HVAC Control																																																															
R	2015	ELR	Body	Headlamp Control Module																																																															
R	2015	ELR	Body	Radio																																																															
R	2015	ELR	Body	Amplifier																																																															
R	2015	ELR	Body	Human Machine Interface Control Module																																																															
R	2015	ELR	Body	Telematics Communication Interface Control Module																																																															
R	2015	ELR	Body	HVAC Control Module																																																															
R	2015	ELR	Body	Electric A/C Compressor Control Module																																																															
R	2015	ELR	Body	Coolant Heater Control Module																																																															
R	2015	ELR	Body	Seat Memory Control Module - Driver																																																															
R	2015	ELR	Body	Keyless Entry Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2015	ELR	Body	Right Side Object Detection Control Module																																																															
R	2015	ELR	Body	Left Side Object Detection Control Module																																																															
R	2015	ELR	Body	Parking Assist Control Module																																																															
R	2015	ELR	Body	Frontview Camera Module																																																															
R	2015	ELR	Body	Steering Column Lock Control Module																																																															
R	2015	ELR	Body	Battery Charger Control Module																																																															
R	2015	ELR	Body	Battery Energy Control Module				V	V	V	V																																																							
R	2016	ELR	Powertrain	Engine Control Module																																																															
R	2016	ELR	Powertrain	Trasmission Control Module																																																															
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module																																																															
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module 2	V							V	V																																																					
R	2016	ELR	Powertrain	Drive Motor Control Module 1																																																															
R	2016	ELR	Powertrain	Drive Motor Control Module 2																																																															
R	2016	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																															
R	2016	ELR	Chassis	Electronic Brake Control Module		V	V																																																												
R	2016	ELR	Chassis	Distance Sensing Cruise Control Module																																																															
R	2016	ELR	Chassis	Parking Brake Control Module																																																															
R	2016	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																															
R	2016	ELR	Chassis	Power Steering Control Module																																																															
R	2016	ELR	Chassis	Steering Wheel Angle Sensor Module																																																															
R	2016	ELR	Chassis	Suspension Control Module																																																															
R	2016	ELR	Body	Body Control Module																																																															
R	2016	ELR	Body	Pedestrian Impact Detection Module																																																															
R	2016	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
R	2016	ELR	Body	Passenger Presence Module																																																															
R	2016	ELR	Body	Instrument Cluster																																																															
R	2016	ELR	Body	Radio/HVAC Control																																																															
R	2016	ELR	Body	Headlamp Control Module																																																															
R	2016	ELR	Body	Radio																																																															
R	2016	ELR	Body	Amplifier																																																															
R	2016	ELR	Body	Human Machine Interface Control Module																																																															
R	2016	ELR	Body	Telematics Communication Interface Control Module																																																															
R	2016	ELR	Body	HVAC Control Module																																																															
R	2016	ELR	Body	Electric A/C Compressor Control Module																																																															
R	2016	ELR	Body	Coolant Heater Control Module																																																															
R	2016	ELR	Body	Seat Memory Control Module - Driver																																																															
R	2016	ELR	Body	Keyless Entry Control Module																																																															
R	2016	ELR	Body	Left Side Object Detection Control Module																																																															
R	2016	ELR	Body	Parking Assist Control Module																																																															
R	2016	ELR	Body	Frontview Camera Module																																																															
R	2016	ELR	Body	Steering Column Lock Control Module																																																															
R	2016	ELR	Body	Battery Charger Control Module																																																															
R	2016	ELR	Body	Battery Energy Control Module				V	V	V	V																																																							
Y	2004	ALL	Powertrain	Engine Control Module																																																															
Y	2004	ALL	Powertrain	Automatic Transmission																																																															
Y	2004	ALL	Chassis	Electronic Brake Control Module																																																															
Y	2004	ALL	Chassis	Electronic Suspension Control																																																															
Y	2004	ALL	Chassis	Steering Wheel and Column																																																															
Y	2004	ALL	Body	Amplifier (Bose)																																																															
Y	2004	ALL	Body	Body Control Module										V	V	V	V	V																																																
Y	2004	ALL	Body	CD Changer																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Y	2004	ALL	Body	Digital Radio Receiver																																																											
Y	2004	ALL	Body	Distance Sensing Cruise Control															V	V	V																																										
Y	2004	ALL	Body	Driver Door Module																																																											
Y	2004	ALL	Body	Driver Door Switch																																																											
Y	2004	ALL	Body	Driver Position Module																																																											
Y	2004	ALL	Body	Folding Top Module																		V	V	V																																								
Y	2004	ALL	Body	Head Up Display																																																											
Y	2004	ALL	Body	HVAC Control Module																					V																																								
Y	2004	ALL	Body	Instrument Panel Cluster																																																												
Y	2004	ALL	Body	Navigation Radio																						V	V																																						
Y	2004	ALL	Body	Passenger Door Module																																																											
Y	2004	ALL	Body	Remote Control Door Lock Receiver																								V	V																																			
Y	2004	ALL	Body	Steering Column Lock Module																																																											
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2005	ALL	Powertrain	Engine Control Module																																																											
Y	2005	ALL	Powertrain	Automatic Transmission																																																											
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2005	ALL	Chassis	Electronic Suspension Control																																																											
Y	2005	ALL	Chassis	Steering Wheel and Column																																																											
Y	2005	ALL	Body	Amplifier (Bose)																																																											
Y	2005	ALL	Body	Body Control Module										V	V	V	V	V																																													
Y	2005	ALL	Body	CD Changer																																																											
Y	2005	ALL	Body	Digital Radio Receiver																																																											
Y	2005	ALL	Body	Distance Sensing Cruise Control															V	V	V																																									
Y	2005	ALL	Body	Driver Door Module																																																											
Y	2005	ALL	Body	Driver Door Switch																																																											
Y	2005	ALL	Body	Driver Position Module																																																											
Y	2005	ALL	Body	Folding Top Module																		V	V	V																																								
Y	2005	ALL	Body	Head Up Display																																																											
Y	2005	ALL	Body	HVAC Control Module																					V																																								
Y	2005	ALL	Body	Instrument Panel Cluster																																																											
Y	2005	ALL	Body	Navigation Radio																						V	V																																					
Y	2005	ALL	Body	Passenger Door Module																																																											
Y	2005	ALL	Body	Remote Control Door Lock Receiver																								V	V																																			
Y	2005	ALL	Body	Steering Column Lock Module																																																											
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2006	(YV)XLR	Powertrain	Engine Control Module																																																											
Y	2006	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																											
Y	2006	(YV)XLR	Powertrain	Automatic Transmission																																																											
Y	2006	(YV)XLR	Chassis	Electronic Brake Control Module																																																											
Y	2006	(YV)XLR	Chassis	Electronic Suspension Control																																																											
Y	2006	(YV)XLR	Chassis	Steering Wheel and Column																																																											
Y	2006	(YV)XLR	Body	Amplifier (Bose)																																																											
Y	2006	(YV)XLR	Body	Body Control Module										V	V	V	V	V																																													
Y	2006	(YV)XLR	Body	CD Changer																																																											
Y	2006	(YV)XLR	Body	Digital Radio Receiver																																																											
Y	2006	(YV)XLR	Body	Distance Sensing Cruise Control															V	V	V									V	V	V																															
Y	2006	(YV)XLR	Body	Driver Door Module																																																											
Y	2006	(YV)XLR	Body	Driver Door Switch																																																											
Y	2006	(YV)XLR	Body	Driver Position Module																																																											
Y	2006	(YV)XLR	Body	Folding Top Module																		V	V	V																																								

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Y	2006	(YV)XLR	Body	Headlamp Control Module																																																												
Y	2006	(YV)XLR	Body	Head Up Display																																																												
Y	2006	(YV)XLR	Body	HVAC Control Module																					V																																							
Y	2006	(YV)XLR	Body	Instrument Panel Cluster																																																											
Y	2006	(YV)XLR	Body	Navigation Radio																						V	V																																					
Y	2006	(YV)XLR	Body	Passenger Door Module																																																											
Y	2006	(YV)XLR	Body	Remote Control Door Lock Receiver																								V	V																																			
Y	2006	(YV)XLR	Body	Steering Column Lock Module																																																											
Y	2006	(YV)XLR	Body	Supplemental Inflatable Restraint																																																											
Y	2006	(YX)XLR-V	Powertrain	Engine Control Module																																																											
Y	2006	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																											
Y	2006	(YX)XLR-V	Powertrain	Automatic Transmission																																																											
Y	2006	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																											
Y	2006	(YX)XLR-V	Chassis	Electronic Suspension Control																																																											
Y	2006	(YX)XLR-V	Chassis	Steering Wheel and Column																																																											
Y	2006	(YX)XLR-V	Body	Amplifier (Bose)																																																											
Y	2006	(YX)XLR-V	Body	Body Control Module										V	V	V	V	V																																													
Y	2006	(YX)XLR-V	Body	CD Changer																																																											
Y	2006	(YX)XLR-V	Body	Digital Radio Receiver																																																											
Y	2006	(YX)XLR-V	Body	Distance Sensing Cruise Control															V	V	V									V	V	V																														
Y	2006	(YX)XLR-V	Body	Driver Door Module																																																										
Y	2006	(YX)XLR-V	Body	Driver Door Switch																																																											
Y	2006	(YX)XLR-V	Body	Driver Position Module																																																											
Y	2006	(YX)XLR-V	Body	Folding Top Module																		V	V	V																																							
Y	2006	(YX)XLR-V	Body	Headlamp Control Module																																																											
Y	2006	(YX)XLR-V	Body	Head Up Display																																																											
Y	2006	(YX)XLR-V	Body	HVAC Control Module																					V																																							
Y	2006	(YX)XLR-V	Body	Instrument Panel Cluster																																																											
Y	2006	(YX)XLR-V	Body	Navigation Radio																						V	V																																				
Y	2006	(YX)XLR-V	Body	Passenger Door Module																																																											
Y	2006	(YX)XLR-V	Body	Remote Control Door Lock Receiver																								V	V																																			
Y	2006	(YX)XLR-V	Body	Steering Column Lock Module																																																											
Y	2006	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																											
Y	2007	(YV)XLR	Powertrain	Engine Control Module																																																											
Y	2007	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																											
Y	2007	(YV)XLR	Powertrain	Transmission Control Module																																																											
Y	2007	(YV)XLR	Chassis	Electronic Brake Control Module																																																											
Y	2007	(YV)XLR	Chassis	Electronic Suspension Control																																																											
Y	2007	(YV)XLR	Body	Amplifier (Bose)																																																											
Y	2007	(YV)XLR	Body	Body Control Module										V	V	V	V	V																																													
Y	2007	(YV)XLR	Body	CD Changer																																																											
Y	2007	(YV)XLR	Body	Digital Radio Receiver																																																											
Y	2007	(YV)XLR	Body	Distance Sensing Cruise Control															V	V	V									V	V	V																														
Y	2007	(YV)XLR	Body	Driver Door Module																																																											
Y	2007	(YV)XLR	Body	Driver Door Switch																																																											
Y	2007	(YV)XLR	Body	Driver Position Module																																																											
Y	2007	(YV)XLR	Body	Folding Top Module																		V	V																																								
Y	2007	(YV)XLR	Body	Headlamp Control Module																																																											
Y	2007	(YV)XLR	Body	Head Up Display																																																											
Y	2007	(YV)XLR	Body	HVAC Control Module																					V																																							
Y	2007	(YV)XLR	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Y	2007	(YV)XLR	Body	Navigation Radio																						V	V																																				
Y	2007	(YV)XLR	Body	Passenger Door Module																																																											
Y	2007	(YV)XLR	Body	Remote Control Door Lock Receiver																								V	V																																		
Y	2007	(YV)XLR	Body	Steering Column Lock Module																																																										
Y	2007	(YV)XLR	Body	Supplemental Inflatable Restraint																																																										
Y	2007	(YX)XLR-V	Powertrain	Engine Control Module																																																										
Y	2007	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	(YX)XLR-V	Powertrain	Transmission Control Module																																																										
Y	2007	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																										
Y	2007	(YX)XLR-V	Chassis	Electronic Suspension Control																																																										
Y	2007	(YX)XLR-V	Body	Amplifier (Bose)																																																										
Y	2007	(YX)XLR-V	Body	Body Control Module										V	V	V	V	V																																												
Y	2007	(YX)XLR-V	Body	CD Changer																																																										
Y	2007	(YX)XLR-V	Body	Digital Radio Receiver																																																										
Y	2007	(YX)XLR-V	Body	Distance Sensing Cruise Control															V	V	V									V	V	V																														
Y	2007	(YX)XLR-V	Body	Driver Door Module																																																										
Y	2007	(YX)XLR-V	Body	Driver Door Switch																																																										
Y	2007	(YX)XLR-V	Body	Driver Position Module																																																										
Y	2007	(YX)XLR-V	Body	Folding Top Module																		V	V																																							
Y	2007	(YX)XLR-V	Body	Headlamp Control Module																																																										
Y	2007	(YX)XLR-V	Body	Head Up Display																																																										
Y	2007	(YX)XLR-V	Body	HVAC Control Module																					V																																						
Y	2007	(YX)XLR-V	Body	Instrument Panel Cluster																																																										
Y	2007	(YX)XLR-V	Body	Navigation Radio																						V	V																																				
Y	2007	(YX)XLR-V	Body	Passenger Door Module																																																										
Y	2007	(YX)XLR-V	Body	Remote Control Door Lock Receiver																								V	V																																		
Y	2007	(YX)XLR-V	Body	Steering Column Lock Module																																																										
Y	2007	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2008	ALL	Chassis	Electronic Suspension Control																																																										
Y	2008	ALL	Body	Amplifier (Bose)																																																										
Y	2008	ALL	Body	Body Control Module										V	V	V	V	V																																												
Y	2008	ALL	Body	CD Changer																																																										
Y	2008	ALL	Body	Digital Radio Receiver																																																										
Y	2008	ALL	Body	Distance Sensing Cruise Control															V	V	V									V	V	V																														
Y	2008	ALL	Body	Driver Door Module																																																										
Y	2008	ALL	Body	Driver Door Switch																																																										
Y	2008	ALL	Body	Driver Position Module																																																										
Y	2008	ALL	Body	Folding Top Module																		V	V																																							
Y	2008	ALL	Body	Headlamp Control Module																																																										
Y	2008	ALL	Body	Head Up Display																																																										
Y	2008	ALL	Body	HVAC Control Module																					V																																						
Y	2008	ALL	Body	Instrument Panel Cluster																																																										
Y	2008	ALL	Body	Navigation Radio																						V	V																																			
Y	2008	ALL	Body	Passenger Door Module																																																										
Y	2008	ALL	Body	Remote Control Door Lock Receiver																								V	V																																		

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Y	2008	ALL	Body	Steering Column Lock Module																																																												
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2008	ALL	Body	Vehicle Comm. Interface Module																																																												
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																												
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																												
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																												
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
Y	2009	ALL	Chassis	Electronic Brake Control Module																													V																															
Y	2009	ALL	Chassis	Electronic Suspension Control																																																												
Y	2009	ALL	Body	Amplifier (Bose)																																																												
Y	2009	ALL	Body	Body Control Module										V	V	V	V	V																																														
Y	2009	ALL	Body	CD Changer																																																												
Y	2009	ALL	Body	Digital Radio Receiver																																																												
Y	2009	ALL	Body	Distance Sensing Cruise Control															V	V	V								V	V	V																															
Y	2009	ALL	Body	Driver Door Module																																																											
Y	2009	ALL	Body	Driver Door Switch																																																											
Y	2009	ALL	Body	Driver Position Module																																																											
Y	2009	ALL	Body	Folding Top Module																		V	V																																								
Y	2009	ALL	Body	Headlamp Control Module																																																											
Y	2009	ALL	Body	Head Up Display																																																											
Y	2009	ALL	Body	HVAC Control Module																					V																																						
Y	2009	ALL	Body	Instrument Panel Cluster																																																											
Y	2009	ALL	Body	Navigation Radio																						V	V																																				
Y	2009	ALL	Body	Passenger Door Module																																																											
Y	2009	ALL	Body	Remote Control Door Lock Receiver																								V	V																																		
Y	2009	ALL	Body	Steering Column Lock Module																																																											
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
1	2013	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2013	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2013	XTS	Powertrain	Fuel Pump Control Module																																																											
1	2013	XTS	Powertrain	Rear Differential Clutch Control Module																																																											
1	2013	XTS	Chassis	Electronic Brake Control Module																																																											
1	2013	XTS	Chassis	Parking Brake Control Module																																																											
1	2013	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2013	XTS	Chassis	Power Steering Control Module																																																											
1	2013	XTS	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2013	XTS	Chassis	Suspension Control Module																														V	V																												
1	2013	XTS	Body	Body Control Module																																																											
1	2013	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2013	XTS	Body	Passenger Presence Module																																																											
1	2013	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
1	2013	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																											
1	2013	XTS	Body	Radio/HVAC Control																																																											
1	2013	XTS	Body	Active Safety Control Module																																																											
1	2013	XTS	Body	Headlamp Control Module																																																											
1	2013	XTS	Body	Radio																																																											
1	2013	XTS	Body	Amplifier																																																											
1	2013	XTS	Body	Human Machine Interface Control Module																																																											
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2013	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2013	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
1	2013	XTS	Body	Seat Memory Control Module																																																												
1	2013	XTS	Body	Keyless Entry Control Module																																																												
1	2013	XTS	Body	Right Side Object Detection Control Module																																																												
1	2013	XTS	Body	Left Side Object Detection Control Module																																																												
1	2013	XTS	Body	Parking Assist Control Module																																																												
1	2013	XTS	Body	Frontview Camera Module																																																												
1	2013	XTS	Body	Long Range Radar Sensor Module																																																												
1	2013	XTS	Body	Left Front Short Range Radar Sensor Module																																																												
1	2013	XTS	Body	Right Front Short Range Radar Sensor Module																																																												
1	2013	XTS	Body	Rear Short Range Radar Sensor Module																																																												
1	2014	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																												
1	2014	XTS	Powertrain	(8) 3.6L LF3 Chassis Control Module																																																												
1	2014	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																												
1	2014	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
1	2014	XTS	Powertrain	(3) 3.6L LFX Chassis Control Module																																																												
1	2014	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
1	2014	XTS	Powertrain	Rear Differential Clutch Control Module																																																												
1	2014	XTS	Chassis	Electronic Brake Control Module																																																												
1	2014	XTS	Chassis	Parking Brake Control Module																																																												
1	2014	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2014	XTS	Chassis	Power Steering Control Module																																																												
1	2014	XTS	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2014	XTS	Chassis	Suspension Control Module																													V	V																														
1	2014	XTS	Body	Body Control Module																																																												
1	2014	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	XTS	Body	Passenger Presence Module																																																												
1	2014	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
1	2014	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
1	2014	XTS	Body	Radio/HVAC Control																																																												
1	2014	XTS	Body	Active Safety Control Module																																																												
1	2014	XTS	Body	Headlamp Control Module																																																												
1	2014	XTS	Body	Radio																																																												
1	2014	XTS	Body	Amplifier																																																												
1	2014	XTS	Body	Media Disc Player																																																												
1	2014	XTS	Body	Human Machine Interface Control Module																																																												
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2014	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
1	2014	XTS	Body	Seat Memory Control Module - Passenger																																																												
1	2014	XTS	Body	Seat Memory Control Module - Driver																																																												
1	2014	XTS	Body	Keyless Entry Control Module																																																												
1	2014	XTS	Body	Right Side Object Detection Control Module																																																												
1	2014	XTS	Body	Left Side Object Detection Control Module																																																												
1	2014	XTS	Body	Parking Assist Control Module																																																												
1	2014	XTS	Body	Frontview Camera Module																																																												
1	2014	XTS	Body	Long Range Radar Sensor Module																																																												
1	2014	XTS	Body	Left Front Short Range Radar Sensor Module																																																												
1	2014	XTS	Body	Right Front Short Range Radar Sensor Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2014	XTS	Body	Rear Short Range Radar Sensor Module																																																												
1	2015	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																												
1	2015	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																												
1	2015	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
1	2015	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
1	2015	XTS	Powertrain	Chassis Control Module																																																												
1	2015	XTS	Powertrain	Rear Differential Clutch Control Module																																																												
1	2015	XTS	Chassis	Electronic Brake Control Module																																																												
1	2015	XTS	Chassis	Parking Brake Control Module																																																												
1	2015	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2015	XTS	Chassis	Power Steering Control Module																																																												
1	2015	XTS	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2015	XTS	Chassis	Suspension Control Module																														V	V																													
1	2015	XTS	Body	Body Control Module																																																												
1	2015	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2015	XTS	Body	Passenger Presence Module																																																												
1	2015	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
1	2015	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
1	2015	XTS	Body	Radio/HVAC Control																																																												
1	2015	XTS	Body	Active Safety Control Module																																																												
1	2015	XTS	Body	Radio																																																												
1	2015	XTS	Body	Amplifier																																																												
1	2015	XTS	Body	Media Disc Player																																																												
1	2015	XTS	Body	Human Machine Interface Control Module																																																												
1	2015	XTS	Body	Telematics Communication Interface Control Module																																																												
1	2015	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2015	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
1	2015	XTS	Body	Seat Memory Control Module - Passenger																																																												
1	2015	XTS	Body	Seat Memory Control Module - Driver																																																												
1	2015	XTS	Body	Keyless Entry Control Module																																																												
1	2015	XTS	Body	Right Side Object Detection Control Module																																																												
1	2015	XTS	Body	Left Side Object Detection Control Module																																																												
1	2015	XTS	Body	Parking Assist Control Module GMLAN																																																												
1	2015	XTS	Body	Parking Assist Control Module DID72History																																																												
1	2015	XTS	Body	Frontview Camera Module																																																												
1	2015	XTS	Body	Long Range Radar Sensor Module																																																												
1	2015	XTS	Body	Left Front Short Range Radar Sensor Module																																																												
1	2015	XTS	Body	Right Front Short Range Radar Sensor Module																																																												
1	2015	XTS	Body	Rear Short Range Radar Sensor Module																																																												
1	2016	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																												
1	2016	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																												
1	2016	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
1	2016	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
1	2016	XTS	Powertrain	Chassis Control Module																																																												
1	2016	XTS	Powertrain	Rear Differential Clutch Control Module																																																												
1	2016	XTS	Chassis	Electronic Brake Control Module																																																												
1	2016	XTS	Chassis	Parking Brake Control Module																																																												
1	2016	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2016	XTS	Chassis	Power Steering Control Module																																																												
1	2016	XTS	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2016	XTS	Chassis	Suspension Control Module																														V	V																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2016	XTS	Body	Body Control Module																																																															
1	2016	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
1	2016	XTS	Body	Passenger Presence Module																																																																
1	2016	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																																
1	2016	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																																
1	2016	XTS	Body	Radio/HVAC Control																																																																
1	2016	XTS	Body	Active Safety Control Module																																																																
1	2016	XTS	Body	Video Processing Control Module																																																																
1	2016	XTS	Body	Radio																																																																
1	2016	XTS	Body	Amplifier																																																																
1	2016	XTS	Body	Media Disc Player																																																																
1	2016	XTS	Body	Human Machine Interface Control Module																																																																
1	2016	XTS	Body	Telematics Communication Interface Control Module																																																																
1	2016	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																																
1	2016	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																																
1	2016	XTS	Body	Seat Memory Control Module - Passenger																																																																
1	2016	XTS	Body	Seat Memory Control Module - Driver																																																																
1	2016	XTS	Body	Keyless Entry Control Module																																																																
1	2016	XTS	Body	Right Side Object Detection Control Module																																																																
1	2016	XTS	Body	Left Side Object Detection Control Module																																																																
1	2016	XTS	Body	Parking Assist Control Module																																																																
1	2016	XTS	Body	Frontview Camera Module																																																																
1	2016	XTS	Body	Steering Column Lock Control Module																																																																
1	2016	XTS	Body	Long Range Radar Sensor Module																																																																
1	2016	XTS	Body	Left Front Short Range Radar Sensor Module																																																																
1	2016	XTS	Body	Right Front Short Range Radar Sensor Module																																																																
1	2016	XTS	Body	Rear Short Range Radar Sensor Module																																																																

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump																																																											
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																											
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Engine Mount																																																											
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2013	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
A	2013	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																											
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump																																																											
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																											
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Engine Mount																																																											
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2013	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump																																																											
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Engine Mount																																																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2013	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
A	2013	ATS	Powertrain	Transfer Case Control Module																																																													
A	2013	ATS	Chassis	Electronic Brake Control Module																																																												
A	2013	ATS	Chassis	Parking Brake Control Module																																																												
A	2013	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2013	ATS	Chassis	Power Steering Control Module																																																												
A	2013	ATS	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2013	ATS	Chassis	Suspension Control Module																																																												
A	2013	ATS	Body	Body Control Module Halogen																																																												
A	2013	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
A	2013	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2013	ATS	Body	Passenger Presence Module																																																												
A	2013	ATS	Body	Pedestrian Impact Detection Module																																																												
A	2013	ATS	Body	Instrument Cluster																																																												
A	2013	ATS	Body	Radio/HVAC Control																																																												
A	2013	ATS	Body	Active Safety Control Module																																																												
A	2013	ATS	Body	Headlamp Control Module																																																												
A	2013	ATS	Body	Trailer Interface Control Module																																																												
A	2013	ATS	Body	Radio																																																												
A	2013	ATS	Body	Amplifier																																																												
A	2013	ATS	Body	Human Machine Interface Control Module																																																												
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 9																																																												
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2013	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
A	2013	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
A	2013	ATS	Body	Seat Memory Control Module																																																												
A	2013	ATS	Body	Keyless Entry Type Without Passive Entry																																																												
A	2013	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																												
A	2013	ATS	Body	Right Side Object Detection Control Module																																																												
A	2013	ATS	Body	Left Side Object Detection Control Module																																																												
A	2013	ATS	Body	Parking Assist Control Module																																																												
A	2013	ATS	Body	Frontview Camera Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2013	ATS	Body	Steering Column Lock Control Module																																																											
A	2013	ATS	Body	Long Range Radar Sensor Module																																																												
A	2013	ATS	Body	Left Front Short Range Radar Sensor Module																																																												
A	2013	ATS	Body	Right Front Short Range Radar Sensor Module																																																												
A	2013	ATS	Body	Rear Short Range Radar Sensor Module																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Engine Control Module																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
A	2014	ATS	Powertrain	Transfer Case Control Module																																																													
A	2014	ATS	Chassis	Electronic Brake Control Module																																																												
A	2014	ATS	Chassis	Parking Brake Control Module																																																												
A	2014	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2014	ATS	Chassis	Power Steering Control Module																																																												
A	2014	ATS	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2014	ATS	Chassis	Suspension Control Module																																																												
A	2014	ATS	Body	Body Control Module Halogen																																																												
A	2014	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
A	2014	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2014	ATS	Body	Passenger Presence Module																																																												
A	2014	ATS	Body	Pedestrian Impact Detection Module																																																												
A	2014	ATS	Body	Instrument Cluster																																																												
A	2014	ATS	Body	Radio/HVAC Control																																																												
A	2014	ATS	Body	Active Safety Control Module																																																												
A	2014	ATS	Body	Headlamp Control Module																																																												
A	2014	ATS	Body	Trailer Interface Control Module																																																												
A	2014	ATS	Body	Radio																																																												
A	2014	ATS	Body	Amplifier																																																												
A	2014	ATS	Body	Media Disc Player																																																												
A	2014	ATS	Body	Human Machine Interface Control Module																																																												
A	2014	ATS	Body	Navigation Control Module																																																												
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 9																																																												
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2014	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
A	2014	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
A	2014	ATS	Body	Seat Memory Control Module - Driver																																																												
A	2014	ATS	Body	Keyless Entry Type Without Passive Entry																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2014	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
A	2014	ATS	Body	Right Side Object Detection Control Module																																																										
A	2014	ATS	Body	Left Side Object Detection Control Module																																																										
A	2014	ATS	Body	Parking Assist Control Module																																																										
A	2014	ATS	Body	Frontview Camera Module																																																										
A	2014	ATS	Body	Steering Column Lock Control Module																																																										
A	2014	ATS	Body	Long Range Radar Sensor Module																																																										
A	2014	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2014	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2014	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Maunal Transmission																																																										
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2014	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2014	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
A	2014	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																										
A	2014	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
A	2014	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2014	CTS	Powertrain	Transfer Case Control Module																																																										
A	2014	CTS	Chassis	Electronic Brake Control Module																																																										
A	2014	CTS	Chassis	Parking Brake Control Module																																																										
A	2014	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	CTS	Chassis	Power Steering Control Module																																																										
A	2014	CTS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	CTS	Chassis	Suspension Control Module																																																										
A	2014	CTS	Body	Body Control Module Headlamp Type Halogen																																																										
A	2014	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	CTS	Body	Passenger Presence Module																																																										
A	2014	CTS	Body	Pedestrian Impact Detection Module																																																										
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2014	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2014	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2014	CTS	Body	Radio/HVAC Control																																																										
A	2014	CTS	Body	Active Safety Control Module																																																										
A	2014	CTS	Body	Headlamp Control Module																																																										
A	2014	CTS	Body	Trailer Interface Control Module																																																										
A	2014	CTS	Body	Radio																																																										
A	2014	CTS	Body	Amplifier																																																										
A	2014	CTS	Body	Human Machine Interface Control Module																																																										
A	2014	CTS	Body	Navigation Control Module																																																										
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2014	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2014	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2014	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2014	CTS	Body	Keyless Entry Control Module																																																										
A	2014	CTS	Body	Right Side Object Detection Control Module																																																										
A	2014	CTS	Body	Left Side Object Detection Control Module																																																										
A	2014	CTS	Body	Parking Assist Control Module																																																										
A	2014	CTS	Body	Frontview Camera Module																																																										
A	2014	CTS	Body	Steering Column Lock Control Module																																																										
A	2014	CTS	Body	Long Range Radar Sensor Module																																																										
A	2014	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2014	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2014	CTS	Body	Rear Short Range Radar Sensor Module																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2015	ATS	Powertrain	Transfer Case Control Module																																																										
A	2015	ATS	Chassis	Electronic Brake Control Module																																																										
A	2015	ATS	Chassis	Parking Brake Control Module																																																										
A	2015	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	ATS	Chassis	Power Steering Control Module																																																										
A	2015	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	ATS	Chassis	Suspension Control Module																																																										
A	2015	ATS	Body	Body Control Module Halogen																																																										
A	2015	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2015	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	ATS	Body	Passenger Presence Module																																																										
A	2015	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2015	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2015	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2015	ATS	Body	Radio/HVAC Control																																																										
A	2015	ATS	Body	Active Safety Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2015	ATS	Body	Headlamp Control Module																																																											
A	2015	ATS	Body	Trailer Interface Control Module																																																												
A	2015	ATS	Body	Radio																																																											
A	2015	ATS	Body	Amplifier																																																											
A	2015	ATS	Body	Media Disc Player																																																											
A	2015	ATS	Body	Human Machine Interface Control Module																																																											
A	2015	ATS	Body	Navigation Control Module																																																											
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																											
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2015	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
A	2015	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
A	2015	ATS	Body	Seat Memory Control Module - Driver																																																											
A	2015	ATS	Body	Keyless Entry Control Module Coupe																																																											
A	2015	ATS	Body	Keyless Entry Control Module Sadan																																																											
A	2015	ATS	Body	Right Side Object Detection Control Module																																																											
A	2015	ATS	Body	Left Side Object Detection Control Module																																																											
A	2015	ATS	Body	Parking Assist Control Module																																																											
A	2015	ATS	Body	Frontview Camera Module																																																											
A	2015	ATS	Body	Steering Column Lock Control Module																																																											
A	2015	ATS	Body	Long Range Radar Sensor Module																																																											
A	2015	ATS	Body	Left Front Short Range Radar Sensor Module																																																											
A	2015	ATS	Body	Right Front Short Range Radar Sensor Module																																																											
A	2015	ATS	Body	Rear Short Range Radar Sensor Module																																																											
A	2015	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																											
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Engine Mount																																																											
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2015	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
A	2015	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																											
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																											
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2015	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																											
A	2015	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																											
A	2015	CTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Engine Mount																																																											
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																											
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																											
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																											
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																											
A	2015	CTS	Powertrain	Transfer Case Control Module																																																											
A	2015	CTS	Chassis	Electronic Brake Control Module																																																											
A	2015	CTS	Chassis	Parking Brake Control Module																																																											
A	2015	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2015	CTS	Chassis	Power Steering Control Module																																																											
A	2015	CTS	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2015	CTS	Chassis	Suspension Control Module																																																											
A	2015	CTS	Body	Body Control Module Headlamp Type Halogen																																																											
A	2015	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
A	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2015	CTS	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2015	CTS	Body	Pedestrian Impact Detection Module																																																											
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Left																																																												
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Right																																																												
A	2015	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
A	2015	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
A	2015	CTS	Body	Active Safety Control Module																																																												
A	2015	CTS	Body	Trailer Interface Control Module																																																												
A	2015	CTS	Body	Radio																																																												
A	2015	CTS	Body	Amplifier																																																												
A	2015	CTS	Body	Human Machine Interface Control Module																																																												
A	2015	CTS	Body	Navigation Control Module																																																												
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																												
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2015	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
A	2015	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
A	2015	CTS	Body	Seat Memory Control Module - Driver																																																												
A	2015	CTS	Body	Keyless Entry Control Module																																																												
A	2015	CTS	Body	Right Side Object Detection Control Module																																																												
A	2015	CTS	Body	Left Side Object Detection Control Module																																																												
A	2015	CTS	Body	Parking Assist Control Module																																																												
A	2015	CTS	Body	Frontview Camera Module																																																												
A	2015	CTS	Body	Steering Column Lock Control Module																																																												
A	2015	CTS	Body	Long Range Radar Sensor Module																																																												
A	2015	CTS	Body	Left Front Short Range Radar Sensor Module																																																												
A	2015	CTS	Body	Right Front Short Range Radar Sensor Module																																																												
A	2015	CTS	Body	Rear Short Range Radar Sensor Module																																																												
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																												
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																												
A	2016	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
A	2016	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Automatic Transmission																																																												
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Manual Transmission																																																												
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Transmission Control Module																																																												
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																												
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																												
A	2016	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
A	2016	ATS	Powertrain	Transfer Case Control Module																																																												
A	2016	ATS	Powertrain	Rear Differential Clutch Control Module																																																												
A	2016	ATS	Chassis	Electronic Brake Control Module																																																												
A	2016	ATS	Chassis	Parking Brake Control Module																																																												
A	2016	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2016	ATS	Chassis	Power Steering Control Module																																																												
A	2016	ATS	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2016	ATS	Chassis	Suspension Control Module																																																												
A	2016	ATS	Body	Body Control Module Halogen																																																												
A	2016	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
A	2016	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2016	ATS	Body	Passenger Presence Module																																																												
A	2016	ATS	Body	Pedestrian Impact Detection Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2016	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2016	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2016	ATS	Body	Radio/HVAC Control																																																										
A	2016	ATS	Body	Vehicle Performance Data Recorder																																																										
A	2016	ATS	Body	Trailer Interface Control Module																																																										
A	2016	ATS	Body	Radio																																																										
A	2016	ATS	Body	Amplifier																																																										
A	2016	ATS	Body	Rear Audio Control Module																																																										
A	2016	ATS	Body	Media Disc Player																																																										
A	2016	ATS	Body	Human Machine Interface Control Module																																																										
A	2016	ATS	Body	Navigation Control Module																																																										
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2016	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2016	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2016	ATS	Body	Seat Memory Control Module - Passenger																																																										
A	2016	ATS	Body	Seat Memory Control Module - Driver																																																										
A	2016	ATS	Body	Keyless Entry Control Module Coupe																																																										
A	2016	ATS	Body	Keyless Entry Control Module Sadan																																																										
A	2016	ATS	Body	Right Side Object Detection Control Module																																																										
A	2016	ATS	Body	Left Side Object Detection Control Module																																																										
A	2016	ATS	Body	Parking Assist Control Module																																																										
A	2016	ATS	Body	Frontview Camera Module																																																										
A	2016	ATS	Body	Steering Column Lock Control Module																																																										
A	2016	ATS	Body	Long Range Radar Sensor Module																																																										
A	2016	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2016	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2016	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2016	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
A	2016	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2016	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
A	2016	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
A	2016	CTS	Powertrain	(S) 3.6L LGX Engine Control Module																																																										
A	2016	CTS	Powertrain	(S) 3.6L LGX Transmission Control Module																																																										
A	2016	CTS	Powertrain	(6) 6.2L LT4 Engine Control Module																																																										
A	2016	CTS	Powertrain	(6) 6.2L LT4 Transmission Control Module																																																										
A	2016	CTS	Powertrain	Rear Differential Clutch Control Module																																																										
A	2016	CTS	Powertrain	Transfer Case Control Module																																																										
A	2016	CTS	Chassis	Electronic Brake Control Module																																																										
A	2016	CTS	Chassis	Parking Brake Control Module																																																										
A	2016	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2016	CTS	Chassis	Power Steering Control Module																																																										
A	2016	CTS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	CTS	Chassis	Suspension Control Module																																																										
A	2016	CTS	Body	Body Control Module Headlamp Type Halogen																																																										
A	2016	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2016	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	CTS	Body	Passenger Presence Module																																																										
A	2016	CTS	Body	Pedestrian Impact Detection Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Left																																																											
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Right																																																												
A	2016	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
A	2016	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
A	2016	CTS	Body	Radio/HVAC Control																																																												
A	2016	CTS	Body	Vehicle Performance Data Recorder																																																												
A	2016	CTS	Body	Active Safety Control Module																																																												
A	2016	CTS	Body	Video Processing Control Module																																																												
A	2016	CTS	Body	Trailer Interface Control Module																																																												
A	2016	CTS	Body	Radio																																																												
A	2016	CTS	Body	Amplifier																																																												
A	2016	CTS	Body	Human Machine Interface Control Module																																																												
A	2016	CTS	Body	Navigation Control Module																																																												
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																												
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2016	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
A	2016	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
A	2016	CTS	Body	Seat Memory Control Module - Passenger																																																												
A	2016	CTS	Body	Seat Memory Control Module - Driver																																																												
A	2016	CTS	Body	Keyless Entry Control Module																																																												
A	2016	CTS	Body	Right Side Object Detection Control Module																																																												
A	2016	CTS	Body	Left Side Object Detection Control Module																																																												
A	2016	CTS	Body	Parking Assist Control Module																																																												
A	2016	CTS	Body	Frontview Camera Module																																																												
A	2016	CTS	Body	Steering Column Lock Control Module																																																												
A	2016	CTS	Body	Long Range Radar Sensor Module																																																												
A	2016	CTS	Body	Left Front Short Range Radar Sensor Module																																																												
A	2016	CTS	Body	Right Front Short Range Radar Sensor Module																																																												
A	2016	CTS	Body	Rear Short Range Radar Sensor Module																																																												
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																												
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																												
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																												
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																												
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																												
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																												
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2004	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2004	(DM)CTS	Chassis	VES																																																												
D	2004	(DM)CTS	Body	Amplifier (Bose)																																																												
D	2004	(DM)CTS	Body	Amplifier (Delco)																																																												
D	2004	(DM)CTS	Body	Climate Control Panel																																																												
D	2004	(DM)CTS	Body	Dash Integration Module																																																												
D	2004	(DM)CTS	Body	Digital Radio Receiver																																																												
D	2004	(DM)CTS	Body	Driver Door Switch																																																												
D	2004	(DM)CTS	Body	Driver Door Module																																																												
D	2004	(DM)CTS	Body	Passenger Door Module																																																												
D	2004	(DM)CTS	Body	Left Rear Door Module																																																												
D	2004	(DM)CTS	Body	Right Rear Door Module																																																												
D	2004	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2004	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2004	(DM)CTS	Body	Instrument Panel Cluster																																																											
D	2004	(DM)CTS	Body	Memory Seat Module																																																												
D	2004	(DM)CTS	Body	Personalization																																																												
D	2004	(DM)CTS	Body	Rear Integration Module																																																												
D	2004	(DM)CTS	Body	Remote Function Actuation																																																												
D	2004	(DM)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2004	(DM)CTS	Body	TV Antenna Module																																																												
D	2004	(DM)CTS	Body	Vehicle Theft Deterrent																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																												
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																												
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																												
D	2004	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2004	(DR)CTS	Chassis	VES																																																												
D	2004	(DR)CTS	Body	Amplifier (Bose)																																																												
D	2004	(DR)CTS	Body	Amplifier (Delco)																																																												
D	2004	(DR)CTS	Body	Climate Control Panel																																																												
D	2004	(DR)CTS	Body	Dash Integration Module																																																												
D	2004	(DR)CTS	Body	Digital Radio Receiver																																																												
D	2004	(DR)CTS	Body	Driver Door Switch																																																												
D	2004	(DR)CTS	Body	Driver Door Module																																																												
D	2004	(DR)CTS	Body	Passenger Door Module																																																												
D	2004	(DR)CTS	Body	Left Rear Door Module																																																												
D	2004	(DR)CTS	Body	Right Rear Door Module																																																												
D	2004	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2004	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2004	(DR)CTS	Body	Instrument Panel Cluster																																																												
D	2004	(DR)CTS	Body	Memory Seat Module																																																												
D	2004	(DR)CTS	Body	Personalization																																																												
D	2004	(DR)CTS	Body	Rear Integration Module																																																												
D	2004	(DR)CTS	Body	Remote Function Actuation																																																												
D	2004	(DR)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2004	(DR)CTS	Body	TV Antenna Module																																																												
D	2004	(DR)CTS	Body	Vehicle Theft Deterrent																																																												
D	2004	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																												
D	2004	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																												
D	2004	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																												
D	2004	(DN)CTS-V	Chassis	VES																																																												
D	2004	(DN)CTS-V	Body	Amplifier (Bose)																																																												
D	2004	(DN)CTS-V	Body	Amplifier (Delco)																																																												
D	2004	(DN)CTS-V	Body	Climate Control Panel																																																												
D	2004	(DN)CTS-V	Body	Dash Integration Module																																																												
D	2004	(DN)CTS-V	Body	Digital Radio Receiver																																																												
D	2004	(DN)CTS-V	Body	Driver Door Switch																																																												
D	2004	(DN)CTS-V	Body	Driver Door Module																																																												
D	2004	(DN)CTS-V	Body	Passenger Door Module																																																												
D	2004	(DN)CTS-V	Body	Left Rear Door Module																																																												
D	2004	(DN)CTS-V	Body	Right Rear Door Module																																																												
D	2004	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2004	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																											
D	2004	(DN)CTS-V	Body	Instrument Panel Cluster																																																												
D	2004	(DN)CTS-V	Body	Memory Seat Module																																																												
D	2004	(DN)CTS-V	Body	Personalization																																																												
D	2004	(DN)CTS-V	Body	Rear Integration Module																																																												
D	2004	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																												
D	2004	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																												
D	2004	(DN)CTS-V	Body	TV Antenna Module																																																												
D	2004	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																												
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																												
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2005	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2005	(DM)CTS	Chassis	VES																																																												
D	2005	(DM)CTS	Body	Amplifier (Bose)																																																												
D	2005	(DM)CTS	Body	Amplifier (Delco)																																																												
D	2005	(DM)CTS	Body	Climate Control Panel																																																												
D	2005	(DM)CTS	Body	Dash Integration Module																																																												
D	2005	(DM)CTS	Body	Digital Radio Receiver																																																												
D	2005	(DM)CTS	Body	Driver Door Switch																																																												
D	2005	(DM)CTS	Body	Driver Door Module																																																												
D	2005	(DM)CTS	Body	Passenger Door Module																																																												
D	2005	(DM)CTS	Body	Left Rear Door Module																																																												
D	2005	(DM)CTS	Body	Right Rear Door Module																																																												
D	2005	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2005	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2005	(DM)CTS	Body	Instrument Panel Cluster																																																												
D	2005	(DM)CTS	Body	Memory Seat Module																																																												
D	2005	(DM)CTS	Body	Personalization																																																												
D	2005	(DM)CTS	Body	Rear Integration Module																																																												
D	2005	(DM)CTS	Body	Remote Control Door Lock Receiver																																																												
D	2005	(DM)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2005	(DM)CTS	Body	TV Antenna Module																																																												
D	2005	(DM)CTS	Body	Vehicle Theft Deterrent																																																												
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																												
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2005	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2005	(DP)CTS	Chassis	VES																																																												
D	2005	(DP)CTS	Body	Amplifier (Bose)																																																												
D	2005	(DP)CTS	Body	Amplifier (Delco)																																																												
D	2005	(DP)CTS	Body	Climate Control Panel																																																												
D	2005	(DP)CTS	Body	Dash Integration Module																																																												
D	2005	(DP)CTS	Body	Digital Radio Receiver																																																												
D	2005	(DP)CTS	Body	Driver Door Switch																																																												
D	2005	(DP)CTS	Body	Driver Door Module																																																												
D	2005	(DP)CTS	Body	Passenger Door Module																																																												
D	2005	(DP)CTS	Body	Left Rear Door Module																																																												
D	2005	(DP)CTS	Body	Right Rear Door Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2005	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2005	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2005	(DP)CTS	Body	Instrument Panel Cluster																																																										
D	2005	(DP)CTS	Body	Memory Seat Module																																																										
D	2005	(DP)CTS	Body	Personalization																																																										
D	2005	(DP)CTS	Body	Rear Integration Module																																																										
D	2005	(DP)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DP)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DP)CTS	Body	TV Antenna Module																																																										
D	2005	(DP)CTS	Body	Vehicle Theft Deterrent																																																										
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2005	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2005	(DR)CTS	Chassis	VES																																																										
D	2005	(DR)CTS	Body	Amplifier (Bose)																																																										
D	2005	(DR)CTS	Body	Amplifier (Delco)																																																										
D	2005	(DR)CTS	Body	Climate Control Panel																																																										
D	2005	(DR)CTS	Body	Dash Integration Module																																																										
D	2005	(DR)CTS	Body	Digital Radio Receiver																																																										
D	2005	(DR)CTS	Body	Driver Door Switch																																																										
D	2005	(DR)CTS	Body	Driver Door Module																																																										
D	2005	(DR)CTS	Body	Passenger Door Module																																																										
D	2005	(DR)CTS	Body	Left Rear Door Module																																																										
D	2005	(DR)CTS	Body	Right Rear Door Module																																																										
D	2005	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2005	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2005	(DR)CTS	Body	Instrument Panel Cluster																																																										
D	2005	(DR)CTS	Body	Memory Seat Module																																																										
D	2005	(DR)CTS	Body	Personalization																																																										
D	2005	(DR)CTS	Body	Radio																																																										
D	2005	(DR)CTS	Body	Rear Integration Module																																																										
D	2005	(DR)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DR)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DR)CTS	Body	TV Antenna Module																																																										
D	2005	(DR)CTS	Body	Vehicle Theft Deterrent																																																										
D	2005	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																										
D	2005	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																										
D	2005	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																										
D	2005	(DN)CTS-V	Chassis	VES																																																										
D	2005	(DN)CTS-V	Body	Amplifier (Bose)																																																										
D	2005	(DN)CTS-V	Body	Amplifier (Delco)																																																										
D	2005	(DN)CTS-V	Body	Climate Control Panel																																																										
D	2005	(DN)CTS-V	Body	Dash Integration Module																																																										
D	2005	(DN)CTS-V	Body	Digital Radio Receiver																																																										
D	2005	(DN)CTS-V	Body	Driver Door Switch																																																										
D	2005	(DN)CTS-V	Body	Driver Door Module																																																										
D	2005	(DN)CTS-V	Body	Passenger Door Module																																																										
D	2005	(DN)CTS-V	Body	Left Rear Door Module																																																										
D	2005	(DN)CTS-V	Body	Right Rear Door Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2005	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																										
D	2005	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																										
D	2005	(DN)CTS-V	Body	Instrument Panel Cluster																																																										
D	2005	(DN)CTS-V	Body	Memory Seat Module																																																										
D	2005	(DN)CTS-V	Body	Personalization																																																										
D	2005	(DN)CTS-V	Body	Radio																																																										
D	2005	(DN)CTS-V	Body	Rear Integration Module																																																										
D	2005	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DN)CTS-V	Body	TV Antenna Module																																																										
D	2005	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																										
D	2005	(DC)STS-V8	Powertrain	Engine Control Module																																																										
D	2005	(DC)STS-V8	Powertrain	Transmission Control Module																																																										
D	2005	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																										
D	2005	(DC)STS-V8	Chassis	Electronic Suspension Control																																																										
D	2005	(DC)STS-V8	Body	Amplifier (Bose)																																																										
D	2005	(DC)STS-V8	Body	Digital Radio Receiver																																																										
D	2005	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																										
D	2005	(DC)STS-V8	Body	Driver Door Module																																																										
D	2005	(DC)STS-V8	Body	Driver Door Switch																																																										
D	2005	(DC)STS-V8	Body	Driver Position Module																																																										
D	2005	(DC)STS-V8	Body	Headlamp Control Module																																																										
D	2005	(DC)STS-V8	Body	Head Up Display																																																										
D	2005	(DC)STS-V8	Body	HVAC Control Module																																																										
D	2005	(DC)STS-V8	Body	Instrument Panel Cluster																																																										
D	2005	(DC)STS-V8	Body	Instrument Panel Module																																																										
D	2005	(DC)STS-V8	Body	Left Rear Door Module																																																										
D	2005	(DC)STS-V8	Body	Passenger Door Module																																																										
D	2005	(DC)STS-V8	Body	Uplevel Radio																																																										
D	2005	(DC)STS-V8	Body	Navigation Radio																																																										
D	2005	(DC)STS-V8	Body	Rear Integration Module																																																										
D	2005	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DC)STS-V8	Body	Right Rear Door Module																																																										
D	2005	(DC)STS-V8	Body	Steering Column Lock Module																																																										
D	2005	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DC)STS-V8	Body	TV Antenna Module																																																										
D	2005	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																										
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2005	(DW)STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2005	(DW)STS	Chassis	Electronic Brake Control Module																																																										
D	2005	(DW)STS	Chassis	Electronic Suspension Control																																																										
D	2005	(DW)STS	Body	Amplifier (Bose)																																																										
D	2005	(DW)STS	Body	Digital Radio Receiver																																																										
D	2005	(DW)STS	Body	Distance Sensing Cruise Control																																																										
D	2005	(DW)STS	Body	Driver Door Module																																																										
D	2005	(DW)STS	Body	Driver Door Switch																																																										
D	2005	(DW)STS	Body	Driver Position Module																																																										
D	2005	(DW)STS	Body	Headlamp Control Module																																																										
D	2005	(DW)STS	Body	Head Up Display																																																										
D	2005	(DW)STS	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2005	(DW)STS	Body	Instrument Panel Cluster																																																												
D	2005	(DW)STS	Body	Instrument Panel Module																																																													
D	2005	(DW)STS	Body	Left Rear Door Module																																																													
D	2005	(DW)STS	Body	Passenger Door Module																																																													
D	2005	(DW)STS	Body	Uplevel Radio																																																													
D	2005	(DW)STS	Body	Navigation Radio																																																													
D	2005	(DW)STS	Body	Rear Integration Module																																																													
D	2005	(DW)STS	Body	Remote Control Door Lock Receiver																																																													
D	2005	(DW)STS	Body	Right Rear Door Module																																																													
D	2005	(DW)STS	Body	Steering Column Lock Module																																																													
D	2005	(DW)STS	Body	Supplemental Inflatable Restraint																																																													
D	2005	(DW)STS	Body	TV Antenna Module																																																													
D	2005	(DW)STS	Body	Vehicle Comm. Interface Module																																																													
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																													
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																													
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
D	2006	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																													
D	2006	(DM)CTS	Chassis	Tire Pressure Monitor																																																													
D	2006	(DM)CTS	Chassis	VES																																																													
D	2006	(DM)CTS	Body	Amplifier (Bose)																																																													
D	2006	(DM)CTS	Body	Amplifier (Delco)																																																													
D	2006	(DM)CTS	Body	Climate Control Panel																																																													
D	2006	(DM)CTS	Body	Dash Integration Module																																																													
D	2006	(DM)CTS	Body	Digital Radio Receiver																																																													
D	2006	(DM)CTS	Body	Driver Door Switch																																																													
D	2006	(DM)CTS	Body	Driver Door Module																																																													
D	2006	(DM)CTS	Body	Passenger Door Module																																																													
D	2006	(DM)CTS	Body	Left Rear Door Module																																																													
D	2006	(DM)CTS	Body	Right Rear Door Module																																																													
D	2006	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																													
D	2006	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																													
D	2006	(DM)CTS	Body	Instrument Panel Cluster																																																													
D	2006	(DM)CTS	Body	Memory Seat Module																																																													
D	2006	(DM)CTS	Body	Personalization																																																													
D	2006	(DM)CTS	Body	Radio																																																													
D	2006	(DM)CTS	Body	Rear Integration Module																																																													
D	2006	(DM)CTS	Body	Remote Control Door Lock Receiver																																																													
D	2006	(DM)CTS	Body	Supplemental Inflatable Restraint																																																													
D	2006	(DM)CTS	Body	TV Antenna Module																																																													
D	2006	(DM)CTS	Body	Vehicle Theft Deterrent																																																													
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																													
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																													
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
D	2006	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																													
D	2006	(DP)CTS	Chassis	Tire Pressure Monitor																																																													
D	2006	(DP)CTS	Chassis	VES																																																													
D	2006	(DP)CTS	Body	Amplifier (Bose)																																																													
D	2006	(DP)CTS	Body	Amplifier (Delco)																																																													
D	2006	(DP)CTS	Body	Climate Control Panel																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2006	(DP)CTS	Body	Dash Integration Module																																																										
D	2006	(DP)CTS	Body	Digital Radio Receiver																																																										
D	2006	(DP)CTS	Body	Driver Door Switch																																																										
D	2006	(DP)CTS	Body	Driver Door Module																																																										
D	2006	(DP)CTS	Body	Passenger Door Module																																																										
D	2006	(DP)CTS	Body	Left Rear Door Module																																																										
D	2006	(DP)CTS	Body	Right Rear Door Module																																																										
D	2006	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2006	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2006	(DP)CTS	Body	Instrument Panel Cluster																																																										
D	2006	(DP)CTS	Body	Memory Seat Module																																																										
D	2006	(DP)CTS	Body	Personalization																																																										
D	2006	(DP)CTS	Body	Radio																																																										
D	2006	(DP)CTS	Body	Rear Integration Module																																																										
D	2006	(DP)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2006	(DP)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2006	(DP)CTS	Body	TV Antenna Module																																																										
D	2006	(DP)CTS	Body	Vehicle Theft Deterrent																																																										
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2006	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2006	(DR)CTS	Chassis	Tire Pressure Monitor																																																										
D	2006	(DR)CTS	Chassis	VES																																																										
D	2006	(DR)CTS	Body	Amplifier (Bose)																																																										
D	2006	(DR)CTS	Body	Amplifier (Delco)																																																										
D	2006	(DR)CTS	Body	Climate Control Panel																																																										
D	2006	(DR)CTS	Body	Dash Integration Module																																																										
D	2006	(DR)CTS	Body	Digital Radio Receiver																																																										
D	2006	(DR)CTS	Body	Driver Door Switch																																																										
D	2006	(DR)CTS	Body	Driver Door Module																																																										
D	2006	(DR)CTS	Body	Passenger Door Module																																																										
D	2006	(DR)CTS	Body	Left Rear Door Module																																																										
D	2006	(DR)CTS	Body	Right Rear Door Module																																																										
D	2006	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2006	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2006	(DR)CTS	Body	Instrument Panel Cluster																																																										
D	2006	(DR)CTS	Body	Memory Seat Module																																																										
D	2006	(DR)CTS	Body	Personalization																																																										
D	2006	(DR)CTS	Body	Radio																																																										
D	2006	(DR)CTS	Body	Rear Integration Module																																																										
D	2006	(DR)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2006	(DR)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2006	(DR)CTS	Body	TV Antenna Module																																																										
D	2006	(DR)CTS	Body	Vehicle Theft Deterrent																																																										
D	2006	(DN)CTS-V	Powertrain	Engine Control Module																																																										
D	2006	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																										
D	2006	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																										
D	2006	(DN)CTS-V	Chassis	VES																																																										
D	2006	(DN)CTS-V	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2006	(DN)CTS-V	Body	Amplifier (Delco)																																																										
D	2006	(DN)CTS-V	Body	Climate Control Panel																																																										
D	2006	(DN)CTS-V	Body	Dash Integration Module																																																										
D	2006	(DN)CTS-V	Body	Digital Radio Receiver																																																										
D	2006	(DN)CTS-V	Body	Driver Door Switch																																																										
D	2006	(DN)CTS-V	Body	Driver Door Module																																																										
D	2006	(DN)CTS-V	Body	Passenger Door Module																																																										
D	2006	(DN)CTS-V	Body	Left Rear Door Module																																																										
D	2006	(DN)CTS-V	Body	Right Rear Door Module																																																										
D	2006	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																										
D	2006	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																										
D	2006	(DN)CTS-V	Body	Instrument Panel Cluster																																																										
D	2006	(DN)CTS-V	Body	Memory Seat Module																																																										
D	2006	(DN)CTS-V	Body	Personalization																																																										
D	2006	(DN)CTS-V	Body	Rear Integration Module																																																										
D	2006	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																										
D	2006	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																										
D	2006	(DN)CTS-V	Body	TV Antenna Module																																																										
D	2006	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																										
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Engine Controls																																																										
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2006	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																										
D	2006	(DC)STS-V8	Chassis	Electronic Suspension Control																																																										
D	2006	(DC)STS-V8	Body	Amplifier (Bose)																																																										
D	2006	(DC)STS-V8	Body	Digital Radio Receiver																																																										
D	2006	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																										
D	2006	(DC)STS-V8	Body	Driver Door Module																																																										
D	2006	(DC)STS-V8	Body	Driver Door Switch																																																										
D	2006	(DC)STS-V8	Body	Driver Position Module																																																										
D	2006	(DC)STS-V8	Body	Headlamp Control Module																																																										
D	2006	(DC)STS-V8	Body	Head Up Display																																																										
D	2006	(DC)STS-V8	Body	HVAC Control Module																																																										
D	2006	(DC)STS-V8	Body	Instrument Panel Cluster																																																										
D	2006	(DC)STS-V8	Body	Instrument Panel Module																																																										
D	2006	(DC)STS-V8	Body	Left Rear Door Module																																																										
D	2006	(DC)STS-V8	Body	Passenger Door Module																																																										
D	2006	(DC)STS-V8	Body	Uplevel Radio																																																										
D	2006	(DC)STS-V8	Body	Navigation Radio																																																										
D	2006	(DC)STS-V8	Body	Rear Integration Module																																																										
D	2006	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																										
D	2006	(DC)STS-V8	Body	Right Rear Door Module																																																										
D	2006	(DC)STS-V8	Body	Steering Column Lock Module																																																										
D	2006	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																										
D	2006	(DC)STS-V8	Body	TV Antenna Module																																																										
D	2006	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																										
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2006	(DW)STS	Chassis	Electronic Brake Control Module																																																										
D	2006	(DW)STS	Chassis	Electronic Suspension Control																																																										
D	2006	(DW)STS	Body	Amplifier (Bose)																																																										
D	2006	(DW)STS	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2006	(DW)STS	Body	Distance Sensing Cruise Control																																																										
D	2006	(DW)STS	Body	Driver Door Module																																																										
D	2006	(DW)STS	Body	Driver Door Switch																																																										
D	2006	(DW)STS	Body	Driver Position Module																																																										
D	2006	(DW)STS	Body	Headlamp Control Module																																																										
D	2006	(DW)STS	Body	Head Up Display																																																										
D	2006	(DW)STS	Body	HVAC Control Module																																																										
D	2006	(DW)STS	Body	Instrument Panel Cluster																																																										
D	2006	(DW)STS	Body	Instrument Panel Module																																																										
D	2006	(DW)STS	Body	Left Rear Door Module																																																										
D	2006	(DW)STS	Body	Passenger Door Module																																																										
D	2006	(DW)STS	Body	Uplevel Radio																																																										
D	2006	(DW)STS	Body	Navigation Radio																																																										
D	2006	(DW)STS	Body	Rear Integration Module																																																										
D	2006	(DW)STS	Body	Remote Control Door Lock Receiver																																																										
D	2006	(DW)STS	Body	Right Rear Door Module																																																										
D	2006	(DW)STS	Body	Steering Column Lock Module																																																										
D	2006	(DW)STS	Body	Supplemental Inflatable Restraint																																																										
D	2006	(DW)STS	Body	TV Antenna Module																																																										
D	2006	(DW)STS	Body	Vehicle Comm. Interface Module																																																										
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
D	2006	(DX)STS-V	Chassis	Electronic Brake Control Module																																																										
D	2006	(DX)STS-V	Chassis	Electronic Suspension Control																																																										
D	2006	(DX)STS-V	Body	Amplifier (Bose)																																																										
D	2006	(DX)STS-V	Body	Digital Radio Receiver																																																										
D	2006	(DX)STS-V	Body	Distance Sensing Cruise Control																																																										
D	2006	(DX)STS-V	Body	Driver Door Module																																																										
D	2006	(DX)STS-V	Body	Driver Door Switch																																																										
D	2006	(DX)STS-V	Body	Driver Position Module																																																										
D	2006	(DX)STS-V	Body	Headlamp Control Module																																																										
D	2006	(DX)STS-V	Body	Head Up Display																																																										
D	2006	(DX)STS-V	Body	HVAC Control Module																																																										
D	2006	(DX)STS-V	Body	Instrument Panel Cluster																																																										
D	2006	(DX)STS-V	Body	Instrument Panel Module																																																										
D	2006	(DX)STS-V	Body	Left Rear Door Module																																																										
D	2006	(DX)STS-V	Body	Passenger Door Module																																																										
D	2006	(DX)STS-V	Body	Uplevel Radio																																																										
D	2006	(DX)STS-V	Body	Navigation Radio																																																										
D	2006	(DX)STS-V	Body	Rear Integration Module																																																										
D	2006	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																										
D	2006	(DX)STS-V	Body	Right Rear Door Module																																																										
D	2006	(DX)STS-V	Body	Steering Column Lock Module																																																										
D	2006	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																										
D	2006	(DX)STS-V	Body	TV Antenna Module																																																										
D	2006	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																										
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																										
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																										
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																										
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2007	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2007	(DM)CTS	Chassis	VES																																																											
D	2007	(DM)CTS	Body	Amplifier (Bose)																																																											
D	2007	(DM)CTS	Body	Amplifier (Delco)																																																											
D	2007	(DM)CTS	Body	Climate Control Panel																																																											
D	2007	(DM)CTS	Body	Dash Integration Module																																																											
D	2007	(DM)CTS	Body	Digital Radio Receiver																																																											
D	2007	(DM)CTS	Body	Driver Door Switch																																																											
D	2007	(DM)CTS	Body	Driver Door Module																																																											
D	2007	(DM)CTS	Body	Passenger Door Module																																																											
D	2007	(DM)CTS	Body	Left Rear Door Module																																																											
D	2007	(DM)CTS	Body	Right Rear Door Module																																																											
D	2007	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2007	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2007	(DM)CTS	Body	Instrument Panel Cluster																																																											
D	2007	(DM)CTS	Body	Memory Seat Module																																																											
D	2007	(DM)CTS	Body	Personalization																																																											
D	2007	(DM)CTS	Body	Rear Integration Module																																																											
D	2007	(DM)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2007	(DM)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2007	(DM)CTS	Body	Theft Deterrent Module																																																											
D	2007	(DM)CTS	Body	TV Antenna Module																																																											
D	2007	(DM)CTS	Body	Vehicle Comm. Interface Module																																																											
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																											
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																											
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																											
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																											
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2007	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2007	(DP)CTS	Chassis	VES																																																											
D	2007	(DP)CTS	Body	Amplifier (Bose)																																																											
D	2007	(DP)CTS	Body	Amplifier (Delco)																																																											
D	2007	(DP)CTS	Body	Climate Control Panel																																																											
D	2007	(DP)CTS	Body	Dash Integration Module																																																											
D	2007	(DP)CTS	Body	Digital Radio Receiver																																																											
D	2007	(DP)CTS	Body	Driver Door Switch																																																											
D	2007	(DP)CTS	Body	Driver Door Module																																																											
D	2007	(DP)CTS	Body	Passenger Door Module																																																											
D	2007	(DP)CTS	Body	Left Rear Door Module																																																											
D	2007	(DP)CTS	Body	Right Rear Door Module																																																											
D	2007	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2007	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2007	(DP)CTS	Body	Instrument Panel Cluster																																																											
D	2007	(DP)CTS	Body	Memory Seat Module																																																											
D	2007	(DP)CTS	Body	Personalization																																																											
D	2007	(DP)CTS	Body	Rear Integration Module																																																											
D	2007	(DP)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2007	(DP)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2007	(DP)CTS	Body	Theft Deterrent Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2007	(DP)CTS	Body	TV Antenna Module																																																												
D	2007	(DP)CTS	Body	Vehicle Comm. Interface Module																																																												
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																												
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																												
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																												
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																												
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2007	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																												
D	2007	(DR)CTS	Chassis	VES																																																												
D	2007	(DR)CTS	Body	Amplifier (Bose)																																																												
D	2007	(DR)CTS	Body	Amplifier (Delco)																																																												
D	2007	(DR)CTS	Body	Climate Control Panel																																																												
D	2007	(DR)CTS	Body	Dash Integration Module																																																												
D	2007	(DR)CTS	Body	Digital Radio Receiver																																																												
D	2007	(DR)CTS	Body	Driver Door Switch																																																												
D	2007	(DR)CTS	Body	Driver Door Module																																																												
D	2007	(DR)CTS	Body	Passenger Door Module																																																												
D	2007	(DR)CTS	Body	Left Rear Door Module																																																												
D	2007	(DR)CTS	Body	Right Rear Door Module																																																												
D	2007	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																												
D	2007	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																												
D	2007	(DR)CTS	Body	Instrument Panel Cluster																																																												
D	2007	(DR)CTS	Body	Memory Seat Module																																																												
D	2007	(DR)CTS	Body	Personalization																																																												
D	2007	(DR)CTS	Body	Rear Integration Module																																																												
D	2007	(DR)CTS	Body	Remote Control Door Lock Receiver																																																												
D	2007	(DR)CTS	Body	Supplemental Inflatable Restraint																																																												
D	2007	(DR)CTS	Body	Theft Deterrent Module																																																												
D	2007	(DR)CTS	Body	TV Antenna Module																																																												
D	2007	(DR)CTS	Body	Vehicle Comm. Interface Module																																																												
D	2007	(DN)CTS-V	Powertrain	(U)6.0L V8 LS2 Engine Control Module																																																												
D	2007	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																												
D	2007	(DN)CTS-V	Chassis	VES																																																												
D	2007	(DN)CTS-V	Body	Amplifier (Bose)																																																												
D	2007	(DN)CTS-V	Body	Amplifier (Delco)																																																												
D	2007	(DN)CTS-V	Body	Climate Control Panel																																																												
D	2007	(DN)CTS-V	Body	Dash Integration Module																																																												
D	2007	(DN)CTS-V	Body	Digital Radio Receiver																																																												
D	2007	(DN)CTS-V	Body	Driver Door Switch																																																												
D	2007	(DN)CTS-V	Body	Driver Door Module																																																												
D	2007	(DN)CTS-V	Body	Passenger Door Module																																																												
D	2007	(DN)CTS-V	Body	Left Rear Door Module																																																												
D	2007	(DN)CTS-V	Body	Right Rear Door Module																																																												
D	2007	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																												
D	2007	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																												
D	2007	(DN)CTS-V	Body	Instrument Panel Cluster																																																												
D	2007	(DN)CTS-V	Body	Memory Seat Module																																																												
D	2007	(DN)CTS-V	Body	Personalization																																																												
D	2007	(DN)CTS-V	Body	Rear Integration Module																																																												
D	2007	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2007	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DN)CTS-V	Body	Theft Deterrent Module																																																										
D	2007	(DN)CTS-V	Body	TV Antenna Module																																																										
D	2007	(DN)CTS-V	Body	Vehicle Comm. Interface Module																																																										
D	2007	(DC)STS-V8	Powertrain	Engine Control Module																																																										
D	2007	(DC)STS-V8	Powertrain	Transmission Control Module																																																										
D	2007	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																										
D	2007	(DC)STS-V8	Chassis	Electronic Suspension Control																																																										
D	2007	(DC)STS-V8	Body	Amplifier (Bose)																																																										
D	2007	(DC)STS-V8	Body	Digital Radio Receiver																																																										
D	2007	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																										
D	2007	(DC)STS-V8	Body	Driver Door Module																																																										
D	2007	(DC)STS-V8	Body	Driver Door Switch																																																										
D	2007	(DC)STS-V8	Body	Driver Position Module																																																										
D	2007	(DC)STS-V8	Body	Headlamp Control Module																																																										
D	2007	(DC)STS-V8	Body	Head Up Display																																																										
D	2007	(DC)STS-V8	Body	HVAC Control Module																																																										
D	2007	(DC)STS-V8	Body	Instrument Panel Cluster																																																										
D	2007	(DC)STS-V8	Body	Instrument Panel Module																																																										
D	2007	(DC)STS-V8	Body	Left Rear Door Module																																																										
D	2007	(DC)STS-V8	Body	Passenger Door Module																																																										
D	2007	(DC)STS-V8	Body	Uplevel Radio																																																										
D	2007	(DC)STS-V8	Body	Navigation Radio																																																										
D	2007	(DC)STS-V8	Body	Rear Integration Module																																																										
D	2007	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																										
D	2007	(DC)STS-V8	Body	Right Rear Door Module																																																										
D	2007	(DC)STS-V8	Body	Steering Column Lock Module																																																										
D	2007	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DC)STS-V8	Body	TV Antenna Module																																																										
D	2007	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																										
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2007	(DW)STS	Chassis	Electronic Brake Control Module																																																										
D	2007	(DW)STS	Chassis	Electronic Suspension Control																																																										
D	2007	(DW)STS	Body	Amplifier (Bose)																																																										
D	2007	(DW)STS	Body	Digital Radio Receiver																																																										
D	2007	(DW)STS	Body	Distance Sensing Cruise Control																																																										
D	2007	(DW)STS	Body	Driver Door Module																																																										
D	2007	(DW)STS	Body	Driver Door Switch																																																										
D	2007	(DW)STS	Body	Driver Position Module																																																										
D	2007	(DW)STS	Body	Headlamp Control Module																																																										
D	2007	(DW)STS	Body	Head Up Display																																																										
D	2007	(DW)STS	Body	HVAC Control Module																																																										
D	2007	(DW)STS	Body	Instrument Panel Cluster																																																										
D	2007	(DW)STS	Body	Instrument Panel Module																																																										
D	2007	(DW)STS	Body	Left Rear Door Module																																																										
D	2007	(DW)STS	Body	Passenger Door Module																																																										
D	2007	(DW)STS	Body	Uplevel Radio																																																										
D	2007	(DW)STS	Body	Navigation Radio																																																										
D	2007	(DW)STS	Body	Rear Integration Module																																																										
D	2007	(DW)STS	Body	Remote Control Door Lock Receiver																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2007	(DW)STS	Body	Right Rear Door Module																																																												
D	2007	(DW)STS	Body	Steering Column Lock Module																																																													
D	2007	(DW)STS	Body	Supplemental Inflatable Restraint																																																												
D	2007	(DW)STS	Body	TV Antenna Module																																																												
D	2007	(DW)STS	Body	Vehicle Comm. Interface Module																																																												
D	2007	(DX)STS-V	Powertrain	Engine Control Module																																																												
D	2007	(DX)STS-V	Powertrain	Transmission Control Module																																																												
D	2007	(DX)STS-V	Chassis	Electronic Brake Control Module																																																												
D	2007	(DX)STS-V	Chassis	Electronic Suspension Control																																																												
D	2007	(DX)STS-V	Body	Amplifier (Bose)																																																												
D	2007	(DX)STS-V	Body	Digital Radio Receiver																																																												
D	2007	(DX)STS-V	Body	Distance Sensing Cruise Control																																																												
D	2007	(DX)STS-V	Body	Driver Door Module																																																												
D	2007	(DX)STS-V	Body	Driver Door Switch																																																												
D	2007	(DX)STS-V	Body	Driver Position Module																																																												
D	2007	(DX)STS-V	Body	Headlamp Control Module																																																												
D	2007	(DX)STS-V	Body	Head Up Display																																																												
D	2007	(DX)STS-V	Body	HVAC Control Module																																																												
D	2007	(DX)STS-V	Body	Instrument Panel Cluster																																																												
D	2007	(DX)STS-V	Body	Instrument Panel Module																																																												
D	2007	(DX)STS-V	Body	Left Rear Door Module																																																												
D	2007	(DX)STS-V	Body	Passenger Door Module																																																												
D	2007	(DX)STS-V	Body	Uplevel Radio																																																												
D	2007	(DX)STS-V	Body	Navigation Radio																																																												
D	2007	(DX)STS-V	Body	Rear Integration Module																																																												
D	2007	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																												
D	2007	(DX)STS-V	Body	Right Rear Door Module																																																												
D	2007	(DX)STS-V	Body	Steering Column Lock Module																																																												
D	2007	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																												
D	2007	(DX)STS-V	Body	TV Antenna Module																																																												
D	2007	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																												
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																												
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																												
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																												
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																												
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																												
D	2008	CTS	Chassis	Electronic Brake Control Module																																																												
D	2008	CTS	Body	Body Control Module																																																												
D	2008	CTS	Body	Body Control Module (aux.)																																																												
D	2008	CTS	Body	Driver Door Switch																																																												
D	2008	CTS	Body	Headlamp Control Module																																																												
D	2008	CTS	Body	HVAC Control Module																																																												
D	2008	CTS	Body	Infotainment Faceplate Module																																																												
D	2008	CTS	Body	Instrument Panel Cluster																																																												
D	2008	CTS	Body	Memory Seat Module																																																												
D	2008	CTS	Body	Park Assist Module																																																												
D	2008	CTS	Body	Passenger Door Switch																																																												
D	2008	CTS	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2008	CTS	Body	Pedestrian Impact Detection Module																																																											
D	2008	CTS	Body	Radio																																																												
D	2008	CTS	Body	Supplemental Inflatable Restraint																																																												
D	2008	CTS	Body	TV Antenna Module																																																												
D	2008	CTS	Body	Vehicle Comm. Interface Module																																																												
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																												
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
D	2008	SLS	Chassis	Electronic Brake Control Module																																																												
D	2008	SLS	Chassis	Electronic Suspension Control																																																												
D	2008	SLS	Body	Amplifier (Bose)																																																												
D	2008	SLS	Body	Driver Door Module																																																												
D	2008	SLS	Body	Driver Door Switch																																																												
D	2008	SLS	Body	Driver Position Module																																																												
D	2008	SLS	Body	Headlamp Control Module																																																												
D	2008	SLS	Body	HVAC Control Module																																																												
D	2008	SLS	Body	Instrument Panel Cluster																																																												
D	2008	SLS	Body	Instrument Panel Module																																																												
D	2008	SLS	Body	Left Rear Door Module																																																												
D	2008	SLS	Body	Passenger Door Module																																																												
D	2008	SLS	Body	Radio																																																												
D	2008	SLS	Body	Rear HVAC/RSA																																																												
D	2008	SLS	Body	Rear Integration Module																																																												
D	2008	SLS	Body	Remote Control Door Lock Receiver																																																												
D	2008	SLS	Body	Right Rear Door Module																																																												
D	2008	SLS	Body	Supplemental Inflatable Restraint																																																												
D	2008	SLS	Body	TV Antenna Module																																																												
D	2008	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																												
D	2008	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																												
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																												
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																												
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
D	2008	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																												
D	2008	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																												
D	2008	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																												
D	2008	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																												
D	2008	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																												
D	2008	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																												
D	2008	STS	Body	Amplifier (Bose)																																																												
D	2008	STS	Body	Digital Radio Receiver																																																												
D	2008	STS	Body	Distance Sensing Cruise Control																																																												
D	2008	STS	Body	Driver Door Module																																																												
D	2008	STS	Body	Driver Door Switch																																																												
D	2008	STS	Body	Driver Position Module																																																												
D	2008	STS	Body	Headlamp Control Module																																																												
D	2008	STS	Body	Head Up Display																																																												
D	2008	STS	Body	HVAC Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2008	STS	Body	Instrument Panel Cluster																																																											
D	2008	STS	Body	Instrument Panel Module																																																												
D	2008	STS	Body	Left Rear Door Module																																																												
D	2008	STS	Body	Left Side Object Detection Module																																																												
D	2008	STS	Body	Passenger Door Module																																																												
D	2008	STS	Body	Uplevel Radio																																																												
D	2008	STS	Body	Navigation Radio																																																												
D	2008	STS	Body	Rear Integration Module																																																												
D	2008	STS	Body	Remote Control Door Lock Receiver																																																												
D	2008	STS	Body	Right Rear Door Module																																																												
D	2008	STS	Body	Right Side Object Detection Module																																																												
D	2008	STS	Body	Steering Column Lock Module																																																												
D	2008	STS	Body	Supplemental Inflatable Restraint																																																												
D	2008	STS	Body	TV Antenna Module																																																												
D	2008	STS	Body	Vehicle Comm. Interface Module																																																												
D	2008	STS	Body	Veh Direction Alert Alarm Warn Mod																																																												
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																												
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																												
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																												
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																												
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																												
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																												
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																												
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																												
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																												
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																												
D	2009	CTS	Chassis	Electronic Brake Control Module																																																												
D	2009	CTS	Chassis	Electronic Suspension Control																																																												
D	2009	CTS	Chassis	Parking Brake Control Module																																																											
D	2009	CTS	Body	Body Control Module																																																											
D	2009	CTS	Body	Body Control Module (aux.)																																																											
D	2009	CTS	Body	Driver Door Switch																																																											
D	2009	CTS	Body	Headlamp Control Module																																																											
D	2009	CTS	Body	HVAC Control Module																																																											
D	2009	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																											
D	2009	CTS	Body	Instrument Panel Cluster (Other)																																																											
D	2009	CTS	Body	Memory Seat Module																																																											
D	2009	CTS	Body	Park Assist Module																																																											
D	2009	CTS	Body	Passenger Door Switch																																																											
D	2009	CTS	Body	Passenger Presence System																																																											
D	2009	CTS	Body	Pedestrian Impact Detection Module																																																											
D	2009	CTS	Body	Radio																																																											
D	2009	CTS	Body	Supplemental Inflatable Restraint																																																											
D	2009	CTS	Body	TV Antenna Module																																																											
D	2009	CTS	Body	Vehicle Comm. Interface Module																																																											
D	2009	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2009	SLS	Powertrain	(T)2.8L V6 LP2 Transmission Control Module																																																											
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2009	SLS	Chassis	Electronic Brake Control Module																																																										
D	2009	SLS	Chassis	Electronic Suspension Control																																																										
D	2009	SLS	Body	Amplifier (Bose)																																																										
D	2009	SLS	Body	Driver Door Module																																																										
D	2009	SLS	Body	Driver Door Switch																																																										
D	2009	SLS	Body	Driver Position Module																																																										
D	2009	SLS	Body	Headlamp Control Module																																																										
D	2009	SLS	Body	HVAC Control Module																																																										
D	2009	SLS	Body	Instrument Panel Cluster																																																										
D	2009	SLS	Body	Instrument Panel Module																																																										
D	2009	SLS	Body	Left Rear Door Module																																																										
D	2009	SLS	Body	Passenger Door Module																																																										
D	2009	SLS	Body	Radio																																																										
D	2009	SLS	Body	Rear HVAC/RSA																																																										
D	2009	SLS	Body	Rear Integration Module																																																										
D	2009	SLS	Body	Remote Control Door Lock Receiver																																																										
D	2009	SLS	Body	Right Rear Door Module																																																										
D	2009	SLS	Body	Supplemental Inflatable Restraint																																																										
D	2009	SLS	Body	TV Antenna Module																																																										
D	2009	SLS	Body	Vehicle Comm. Interface Module																																																										
D	2009	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																										
D	2009	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2009	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																										
D	2009	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																										
D	2009	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																										
D	2009	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																										
D	2009	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																										
D	2009	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																										
D	2009	STS	Body	Amplifier (Bose)																																																										
D	2009	STS	Body	Digital Radio Receiver																																																										
D	2009	STS	Body	Distance Sensing Cruise Control																																																										
D	2009	STS	Body	Driver Door Module																																																										
D	2009	STS	Body	Driver Door Switch																																																										
D	2009	STS	Body	Driver Position Module																																																										
D	2009	STS	Body	Headlamp Control Module																																																										
D	2009	STS	Body	Head Up Display																																																										
D	2009	STS	Body	HVAC Control Module																																																										
D	2009	STS	Body	Instrument Panel Cluster																																																										
D	2009	STS	Body	Instrument Panel Module																																																										
D	2009	STS	Body	Left Rear Door Module																																																										
D	2009	STS	Body	Left Side Object Detection Module																																																										
D	2009	STS	Body	Passenger Door Module																																																										
D	2009	STS	Body	Uplevel Radio																																																										
D	2009	STS	Body	Navigation Radio																																																										
D	2009	STS	Body	Rear Integration Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2009	STS	Body	Remote Control Door Lock Receiver																																																										
D	2009	STS	Body	Right Rear Door Module																																																										
D	2009	STS	Body	Right Side Object Detection Module																																																										
D	2009	STS	Body	Steering Column Lock Module																																																										
D	2009	STS	Body	Supplemental Inflatable Restraint																																																										
D	2009	STS	Body	TV Antenna Module																																																										
D	2009	STS	Body	Vehicle Comm. Interface Module																																																										
D	2009	STS	Body	Veh Direction Alert Alarm Warn Mod																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Auto																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Manual																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transmission Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transfer Case Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module Auto																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																										
D	2010	CTS	Chassis	Electronic Brake Control Module																																																										
D	2010	CTS	Chassis	Electronic Suspension Control																																																										
D	2010	CTS	Chassis	Parking Brake Control Module																																																										
D	2010	CTS	Body	Body Control Module																																																										
D	2010	CTS	Body	Body Control Module (aux.)																																																										
D	2010	CTS	Body	Driver Door Switch																																																										
D	2010	CTS	Body	Headlamp Control Module																																																										
D	2010	CTS	Body	HVAC Control Module																																																										
D	2010	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																										
D	2010	CTS	Body	Instrument Panel Cluster (Other)																																																										
D	2010	CTS	Body	Liftgate Module																																																										
D	2010	CTS	Body	Memory Seat Module																																																										
D	2010	CTS	Body	Park Assist Module																																																										
D	2010	CTS	Body	Passenger Door Switch																																																										
D	2010	CTS	Body	Passenger Presence System																																																										
D	2010	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2010	CTS	Body	Radio																																																										
D	2010	CTS	Body	Supplemental Inflatable Restraint																																																										
D	2010	CTS	Body	TV Antenna Module																																																										
D	2010	CTS	Body	Vehicle Comm. Interface Module																																																										
D	2010	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																										
D	2010	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2010	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																										
D	2010	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2010	STS	Body	Amplifier (Bose)																																																										
D	2010	STS	Body	Digital Radio Receiver																																																										
D	2010	STS	Body	Distance Sensing Cruise Control																																																										
D	2010	STS	Body	Driver Door Module																																																										
D	2010	STS	Body	Driver Door Switch																																																										
D	2010	STS	Body	Driver Position Module																																																										
D	2010	STS	Body	Headlamp Control Module																																																										
D	2010	STS	Body	Head Up Display																																																										
D	2010	STS	Body	HVAC Control Module																																																										
D	2010	STS	Body	Instrument Panel Cluster																																																										
D	2010	STS	Body	Instrument Panel Module																																																										
D	2010	STS	Body	Left Rear Door Module																																																										
D	2010	STS	Body	Left Side Object Detection Module																																																										
D	2010	STS	Body	Passenger Door Module																																																										
D	2010	STS	Body	Uplevel Radio																																																										
D	2010	STS	Body	Navigation Radio																																																										
D	2010	STS	Body	Rear Integration Module																																																										
D	2010	STS	Body	Remote Control Door Lock Receiver																																																										
D	2010	STS	Body	Right Rear Door Module																																																										
D	2010	STS	Body	Right Side Object Detection Module																																																										
D	2010	STS	Body	Steering Column Lock Module																																																										
D	2010	STS	Body	Supplemental Inflatable Restraint																																																										
D	2010	STS	Body	TV Antenna Module																																																										
D	2010	STS	Body	Vehicle Comm. Interface Module																																																										
D	2010	STS	Body	Veh Direction Alert Alarm Warn Mod																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Auto																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Manual																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transfer Case Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Fuel Pump Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transfer Case Control Module																																																										
D	2011	CTS	Chassis	Electronic Brake Control Module																																																										
D	2011	CTS	Chassis	Electronic Suspension Control																																																										
D	2011	CTS	Chassis	Parking Brake Control Module																																																										
D	2011	CTS	Body	Body Control Module (6.2L V8 LSA)																																																										
D	2011	CTS	Body	Body Control Module (Other)																																																										
D	2011	CTS	Body	Body Control Module (aux.)																																																										
D	2011	CTS	Body	Driver Door Switch																																																										
D	2011	CTS	Body	Headlamp Control Module																																																										
D	2011	CTS	Body	HVAC Control Module																																																										
D	2011	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																										
D	2011	CTS	Body	Instrument Panel Cluster (Other)																																																										
D	2011	CTS	Body	Liftgate Module																																																										
D	2011	CTS	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2011	CTS	Body	Park Assist Module																																																										
D	2011	CTS	Body	Passenger Door Switch																																																										
D	2011	CTS	Body	Passenger Presence System																																																										
D	2011	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2011	CTS	Body	Radio																																																										
D	2011	CTS	Body	Supplemental Inflatable Restraint																																																										
D	2011	CTS	Body	TV Antenna Module																																																										
D	2011	CTS	Body	Vehicle Comm. Interface Module																																																										
D	2011	STS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																										
D	2011	STS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																										
D	2011	STS	Chassis	Electronic Brake Control Module																																																										
D	2011	STS	Chassis	Electronic Suspension Control																																																										
D	2011	STS	Body	Amplifier (Bose)																																																										
D	2011	STS	Body	Digital Radio Receiver																																																										
D	2011	STS	Body	Distance Sensing Cruise Control																																																										
D	2011	STS	Body	Driver Door Module																																																										
D	2011	STS	Body	Driver Door Switch																																																										
D	2011	STS	Body	Driver Position Module																																																										
D	2011	STS	Body	Headlamp Control Module																																																										
D	2011	STS	Body	Head Up Display																																																										
D	2011	STS	Body	HVAC Control Module																																																										
D	2011	STS	Body	Instrument Panel Cluster																																																										
D	2011	STS	Body	Instrument Panel Module																																																										
D	2011	STS	Body	Left Rear Door Module																																																										
D	2011	STS	Body	Left Side Object Detection Module																																																										
D	2011	STS	Body	Passenger Door Module																																																										
D	2011	STS	Body	Uplevel Radio																																																										
D	2011	STS	Body	Navigation Radio																																																										
D	2011	STS	Body	Rear Integration Module																																																										
D	2011	STS	Body	Remote Control Door Lock Receiver																																																										
D	2011	STS	Body	Right Rear Door Module																																																										
D	2011	STS	Body	Right Side Object Detection Module																																																										
D	2011	STS	Body	Supplemental Inflatable Restraint																																																										
D	2011	STS	Body	TV Antenna Module																																																										
D	2011	STS	Body	Vehicle Comm. Interface Module																																																										
D	2011	STS	Body	Veh Direction Alert Alarm Warn Mod																																																										
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2012	P Type Engine	Chassis	Electronic Brake Control Module																																																										
D	2012	P Type Engine	Chassis	Electronic Suspension Control																																																										
D	2012	P Type Engine	Chassis	Parking Brake Control Module																																																										
D	2012	P Type Engine	Body	Body Control Module																																																										
D	2012	P Type Engine	Body	Body Control Module (aux.)																																																										
D	2012	P Type Engine	Body	Driver Door Switch																																																										
D	2012	P Type Engine	Body	Headlamp Control Module																																																										
D	2012	P Type Engine	Body	HVAC Control Module																																																										
D	2012	P Type Engine	Body	Instrument Panel Cluster																																																										
D	2012	P Type Engine	Body	Left Side Object Detection Module																																																										
D	2012	P Type Engine	Body	Liftgate Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2012	P Type Engine	Body	Memory Seat Module																																																												
D	2012	P Type Engine	Body	Park Assist Module																																																													
D	2012	P Type Engine	Body	Passenger Door Switch																																																													
D	2012	P Type Engine	Body	Passenger Presence System																																																													
D	2012	P Type Engine	Body	Pedestrian Impact Detection Module																																																													
D	2012	P Type Engine	Body	Radio																																																													
D	2012	P Type Engine	Body	Right Side Object Detection Module																																																													
D	2012	P Type Engine	Body	Supplemental Inflatable Restraint																																																													
D	2012	P Type Engine	Body	TV Antenna Module																																																													
D	2012	P Type Engine	Body	Vehicle Comm. Interface Module																																																													
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto																																																													
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual																																																													
D	2012	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																													
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																													
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																													
D	2012	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																													
D	2012	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																													
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																													
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																													
D	2012	Other	Chassis	Electronic Brake Control Module																																																													
D	2012	Other	Chassis	Electronic Suspension Control																																																													
D	2012	Other	Chassis	Parking Brake Control Module																																																													
D	2012	Other	Body	Body Control Module																																																													
D	2012	Other	Body	Body Control Module (aux.)																																																													
D	2012	Other	Body	Driver Door Switch																																																													
D	2012	Other	Body	Headlamp Control Module																																																													
D	2012	Other	Body	HVAC Control Module																																																													
D	2012	Other	Body	Instrument Panel Cluster																																																													
D	2012	Other	Body	Left Side Object Detection Module																																																													
D	2012	Other	Body	Liftgate Module																																																													
D	2012	Other	Body	Memory Seat Module																																																													
D	2012	Other	Body	Park Assist Module																																																													
D	2012	Other	Body	Passenger Door Switch																																																													
D	2012	Other	Body	Passenger Presence System																																																													
D	2012	Other	Body	Pedestrian Impact Detection Module																																																													
D	2012	Other	Body	Radio																																																													
D	2012	Other	Body	Right Side Object Detection Module																																																													
D	2012	Other	Body	Supplemental Inflatable Restraint																																																													
D	2012	Other	Body	TV Antenna Module																																																													
D	2012	Other	Body	Vehicle Comm. Interface Module																																																													
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																													
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																													
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																													
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																													
D	2013	P Type Engine	Chassis	Electronic Brake Control Module																																																													
D	2013	P Type Engine	Chassis	Electronic Suspension Control																																																													
D	2013	P Type Engine	Chassis	Parking Brake Control Module																																																													
D	2013	P Type Engine	Body	Body Control Module																																																													
D	2013	P Type Engine	Body	Body Control Module (aux.)																																																													
D	2013	P Type Engine	Body	Driver Door Switch																																																													
D	2013	P Type Engine	Body	Headlamp Control Module																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2013	P Type Engine	Body	HVAC Control Module																																																										
D	2013	P Type Engine	Body	Instrument Panel Cluster																																																										
D	2013	P Type Engine	Body	Left Side Object Detection Module																																																										
D	2013	P Type Engine	Body	Liftgate Module																																																										
D	2013	P Type Engine	Body	Memory Seat Module																																																										
D	2013	P Type Engine	Body	Park Assist Module																																																										
D	2013	P Type Engine	Body	Passenger Door Switch																																																										
D	2013	P Type Engine	Body	Passenger Presence System																																																										
D	2013	P Type Engine	Body	Pedestrian Impact Detection Module																																																										
D	2013	P Type Engine	Body	Radio																																																										
D	2013	P Type Engine	Body	Right Side Object Detection Module																																																										
D	2013	P Type Engine	Body	Supplemental Inflatable Restraint																																																										
D	2013	P Type Engine	Body	TV Antenna Module																																																										
D	2013	P Type Engine	Body	Vehicle Comm. Interface Module																																																										
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto																																																										
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual																																																										
D	2013	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																										
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																										
D	2013	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
D	2013	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																										
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																										
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																										
D	2013	Other	Chassis	Electronic Brake Control Module																																																										
D	2013	Other	Chassis	Electronic Suspension Control																																																										
D	2013	Other	Chassis	Parking Brake Control Module																																																										
D	2013	Other	Body	Body Control Module																																																										
D	2013	Other	Body	Body Control Module (aux.)																																																										
D	2013	Other	Body	Driver Door Switch																																																										
D	2013	Other	Body	Headlamp Control Module																																																										
D	2013	Other	Body	HVAC Control Module																																																										
D	2013	Other	Body	Instrument Panel Cluster																																																										
D	2013	Other	Body	Left Side Object Detection Module																																																										
D	2013	Other	Body	Liftgate Module																																																										
D	2013	Other	Body	Memory Seat Module																																																										
D	2013	Other	Body	Park Assist Module																																																										
D	2013	Other	Body	Passenger Door Switch																																																										
D	2013	Other	Body	Passenger Presence System																																																										
D	2013	Other	Body	Pedestrian Impact Detection Module																																																										
D	2013	Other	Body	Radio																																																										
D	2013	Other	Body	Right Side Object Detection Module																																																										
D	2013	Other	Body	Supplemental Inflatable Restraint																																																										
D	2013	Other	Body	TV Antenna Module																																																										
D	2013	Other	Body	Vehicle Comm. Interface Module																																																										
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
D	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
D	2014	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																										
D	2014	CTS	Powertrain	Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2014	CTS	Powertrain	Transfer Case Control Module																																																								
D	2014	CTS	Chassis	Electronic Brake Control Module																																																										
D	2014	CTS	Chassis	Parking Brake Control Module																																																										
D	2014	CTS	Chassis	Suspension Control Module																																																										
D	2014	CTS	Body	Body Control Module Coupe																																																										
D	2014	CTS	Body	Body Control Module Station Wagon																																																										
D	2014	CTS	Body	Auxiliary Body Control Module																																																										
D	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	CTS	Body	Passenger Presence Module																																																										
D	2014	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2014	CTS	Body	Instrument Cluster																																																										
D	2014	CTS	Body	Headlamp Control Module																																																										
D	2014	CTS	Body	Radio																																																										
D	2014	CTS	Body	Amplifier																																																										
D	2014	CTS	Body	Television Antenna Module																																																										
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																										
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2014	CTS	Body	HVAC Control Module																																																										
D	2014	CTS	Body	Driver Door Switch Panel Control Module																																																										
D	2014	CTS	Body	Passenger Door Switch Panel Control Module																																																										
D	2014	CTS	Body	Liftgate Control Module																																																										
D	2014	CTS	Body	Seat Memory Control Module																																																										
D	2014	CTS	Body	Right Side Object Detection Control Module																																																										
D	2014	CTS	Body	Left Side Object Detection Control Module																																																										
D	2014	CTS	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
D	2014	CTS	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
D	2014	CTS	Body	Parking Assist Control Module																																																										
D	2014	CTS	Body	Theft Deterrent Module																																																										
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
D	2015	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																										
D	2015	CTS	Powertrain	Chassis Control Module																																																										
D	2015	CTS	Powertrain	Transfer Case Control Module																																																										
D	2015	CTS	Chassis	Electronic Brake Control Module																																																										
D	2015	CTS	Chassis	Parking Brake Control Module																																																										
D	2015	CTS	Chassis	Suspension Control Module																																																										
D	2015	CTS	Body	Body Control Module Coupe																																																										
D	2015	CTS	Body	Body Control Module Station Wagon																																																										
D	2015	CTS	Body	Auxiliary Body Control Module																																																										
D	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	CTS	Body	Passenger Presence Module																																																										
D	2015	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2015	CTS	Body	Instrument Cluster																																																										
D	2015	CTS	Body	Headlamp Control Module																																																										
D	2015	CTS	Body	Radio																																																										
D	2015	CTS	Body	Amplifier																																																										
D	2015	CTS	Body	Television Antenna Module																																																										
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 9																																																										
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2015	CTS	Body	HVAC Control Module																																																										
D	2015	CTS	Body	Driver Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2015	CTS	Body	Passenger Door Switch Panel Control Module																																																											
D	2015	CTS	Body	Liftgate Control Module																																																												
D	2015	CTS	Body	Seat Memory Control Module																																																												
D	2015	CTS	Body	Right Side Object Detection Control Module																																																												
D	2015	CTS	Body	Left Side Object Detection Control Module																																																												
D	2015	CTS	Body	Remote Control Door Lock Receiver																																																												
D	2015	CTS	Body	Parking Assist Control Module																																																												
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																												
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																												
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																												
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																												
K	2004	(KD)Deville	Body	Amplifier (Delco)																																																												
K	2004	(KD)Deville	Body	CD Changer																																																												
K	2004	(KD)Deville	Body	Dash Integration Module																																																												
K	2004	(KD)Deville	Body	Digital Radio Receiver																																																												
K	2004	(KD)Deville	Body	Driver Door Switch																																																												
K	2004	(KD)Deville	Body	Driver Door Module																																																												
K	2004	(KD)Deville	Body	Passenger Door Module																																																												
K	2004	(KD)Deville	Body	Left Rear Door Module																																																												
K	2004	(KD)Deville	Body	Right Rear Door Module																																																												
K	2004	(KD)Deville	Body	Instrument Panel Cluster																																																												
K	2004	(KD)Deville	Body	Instrument Panel Module																																																												
K	2004	(KD)Deville	Body	Memory Seat Module																																																												
K	2004	(KD)Deville	Body	Navigation Radio																																																												
K	2004	(KD)Deville	Body	Radio																																																												
K	2004	(KD)Deville	Body	Rear Climate Control Panel																																																												
K	2004	(KD)Deville	Body	Rear Integration Module																																																												
K	2004	(KD)Deville	Body	Remote Function Actuation																																																												
K	2004	(KD)Deville	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KD)Deville	Body	Tilt Telescope Module																																																												
K	2004	(KD)Deville	Body	Vehicle Theft Deterrent																																																												
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																												
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																												
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																												
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																												
K	2004	(KE)DHS	Body	Amplifier (Bose)																																																												
K	2004	(KE)DHS	Body	CD Changer																																																												
K	2004	(KE)DHS	Body	Dash Integration Module																																																												
K	2004	(KE)DHS	Body	Digital Radio Receiver																																																												
K	2004	(KE)DHS	Body	Driver Door Switch																																																												
K	2004	(KE)DHS	Body	Driver Door Module																																																												
K	2004	(KE)DHS	Body	Passenger Door Module																																																												
K	2004	(KE)DHS	Body	Left Rear Door Module																																																												
K	2004	(KE)DHS	Body	Right Rear Door Module																																																												
K	2004	(KE)DHS	Body	Instrument Panel Cluster																																																												
K	2004	(KE)DHS	Body	Instrument Panel Module																																																												
K	2004	(KE)DHS	Body	Memory Seat Module																																																												
K	2004	(KE)DHS	Body	Navigation Radio																																																												
K	2004	(KE)DHS	Body	Radio																																																												
K	2004	(KE)DHS	Body	Rear Climate Control Panel																																																												
K	2004	(KE)DHS	Body	Rear Integration Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2004	(KE)DHS	Body	Remote Function Actuation																																																											
K	2004	(KE)DHS	Body	Supplemental Inflatable Restraint																																																											
K	2004	(KE)DHS	Body	Tilt Telescope Module																																																											
K	2004	(KE)DHS	Body	Vehicle Theft Deterrent																																																											
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																											
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																											
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																											
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																											
K	2004	(KF)DTS	Body	Amplifier (Bose)																																																												
K	2004	(KF)DTS	Body	CD Changer																																																												
K	2004	(KF)DTS	Body	Dash Integration Module																																																												
K	2004	(KF)DTS	Body	Digital Radio Receiver																																																												
K	2004	(KF)DTS	Body	Driver Door Switch																																																												
K	2004	(KF)DTS	Body	Driver Door Module																																																												
K	2004	(KF)DTS	Body	Passenger Door Module																																																												
K	2004	(KF)DTS	Body	Left Rear Door Module																																																												
K	2004	(KF)DTS	Body	Right Rear Door Module																																																												
K	2004	(KF)DTS	Body	Instrument Panel Cluster																																																												
K	2004	(KF)DTS	Body	Instrument Panel Module																																																												
K	2004	(KF)DTS	Body	Memory Seat Module																																																												
K	2004	(KF)DTS	Body	Navigation Radio																																																												
K	2004	(KF)DTS	Body	Radio																																																												
K	2004	(KF)DTS	Body	Rear Climate Control Panel																																																												
K	2004	(KF)DTS	Body	Rear Integration Module																																																												
K	2004	(KF)DTS	Body	Remote Function Actuation																																																												
K	2004	(KF)DTS	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KF)DTS	Body	Tilt Telescope Module																																																												
K	2004	(KF)DTS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																												
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																												
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																												
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																												
K	2004	(KS)Seville SLS	Body	Amplifier (Bose)																																																												
K	2004	(KS)Seville SLS	Body	Amplifier (Delco)																																																												
K	2004	(KS)Seville SLS	Body	CD Changer																																																												
K	2004	(KS)Seville SLS	Body	Dash Integration Module																																																												
K	2004	(KS)Seville SLS	Body	Digital Radio Receiver																																																												
K	2004	(KS)Seville SLS	Body	Driver Door Module																																																												
K	2004	(KS)Seville SLS	Body	Instrument Panel Cluster																																																												
K	2004	(KS)Seville SLS	Body	Instrument Panel Module																																																												
K	2004	(KS)Seville SLS	Body	Memory Seat Module																																																												
K	2004	(KS)Seville SLS	Body	Navigation Radio																																																												
K	2004	(KS)Seville SLS	Body	Radio																																																												
K	2004	(KS)Seville SLS	Body	Rear Integration Module																																																												
K	2004	(KS)Seville SLS	Body	Remote Function Actuation																																																												
K	2004	(KS)Seville SLS	Body	Supplemental Inflatable Restraint																																																												
K	2004	(KS)Seville SLS	Body	Tilt Telescope Module																																																												
K	2004	(KS)Seville SLS	Body	Vehicle Theft Deterrent																																																												
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																												
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																												
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2004	(KY)Seville STS	Body	Amplifier (Bose)																																																										
K	2004	(KY)Seville STS	Body	Amplifier (Delco)																																																										
K	2004	(KY)Seville STS	Body	CD Changer																																																										
K	2004	(KY)Seville STS	Body	Dash Integration Module																																																										
K	2004	(KY)Seville STS	Body	Digital Radio Receiver																																																										
K	2004	(KY)Seville STS	Body	Driver Door Module																																																										
K	2004	(KY)Seville STS	Body	Instrument Panel Cluster																																																										
K	2004	(KY)Seville STS	Body	Instrument Panel Module																																																										
K	2004	(KY)Seville STS	Body	Memory Seat Module																																																										
K	2004	(KY)Seville STS	Body	Navigation Radio																																																										
K	2004	(KY)Seville STS	Body	Radio																																																										
K	2004	(KY)Seville STS	Body	Rear Integration Module																																																										
K	2004	(KY)Seville STS	Body	Remote Function Actuation																																																										
K	2004	(KY)Seville STS	Body	Supplemental Inflatable Restraint																																																										
K	2004	(KY)Seville STS	Body	Tilt Telescope Module																																																										
K	2004	(KY)Seville STS	Body	Vehicle Theft Deterrent																																																										
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2005	(KD)Deville	Body	Amplifier (Delco)																																																										
K	2005	(KD)Deville	Body	CD Changer																																																										
K	2005	(KD)Deville	Body	Dash Integration Module																																																										
K	2005	(KD)Deville	Body	Digital Radio Receiver																																																										
K	2005	(KD)Deville	Body	Driver Door Switch																																																										
K	2005	(KD)Deville	Body	Driver Door Module																																																										
K	2005	(KD)Deville	Body	Passenger Door Module																																																										
K	2005	(KD)Deville	Body	Left Rear Door Module																																																										
K	2005	(KD)Deville	Body	Right Rear Door Module																																																										
K	2005	(KD)Deville	Body	Instrument Panel Cluster																																																										
K	2005	(KD)Deville	Body	Instrument Panel Module																																																										
K	2005	(KD)Deville	Body	Memory Seat Module																																																										
K	2005	(KD)Deville	Body	Navigation Radio																																																										
K	2005	(KD)Deville	Body	Radio																																																										
K	2005	(KD)Deville	Body	Rear Climate Control Panel																																																										
K	2005	(KD)Deville	Body	Rear Integration Module																																																										
K	2005	(KD)Deville	Body	Remote Function Actuation																																																										
K	2005	(KD)Deville	Body	Supplemental Inflatable Restraint																																																										
K	2005	(KD)Deville	Body	Tilt Telescope Module																																																										
K	2005	(KD)Deville	Body	Vehicle Theft Deterrent																																																										
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2005	(KE)DHS	Body	Amplifier (Bose)																																																										
K	2005	(KE)DHS	Body	CD Changer																																																										
K	2005	(KE)DHS	Body	Dash Integration Module																																																										
K	2005	(KE)DHS	Body	Digital Radio Receiver																																																										
K	2005	(KE)DHS	Body	Driver Door Switch																																																										
K	2005	(KE)DHS	Body	Driver Door Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2005	(KE)DHS	Body	Passenger Door Module																																																												
K	2005	(KE)DHS	Body	Left Rear Door Module																																																													
K	2005	(KE)DHS	Body	Right Rear Door Module																																																													
K	2005	(KE)DHS	Body	Instrument Panel Cluster																																																													
K	2005	(KE)DHS	Body	Instrument Panel Module																																																													
K	2005	(KE)DHS	Body	Memory Seat Module																																																													
K	2005	(KE)DHS	Body	Navigation Radio																																																													
K	2005	(KE)DHS	Body	Radio																																																													
K	2005	(KE)DHS	Body	Rear Climate Control Panel																																																													
K	2005	(KE)DHS	Body	Rear Integration Module																																																													
K	2005	(KE)DHS	Body	Remote Function Actuation																																																													
K	2005	(KE)DHS	Body	Supplemental Inflatable Restraint																																																													
K	2005	(KE)DHS	Body	Tilt Telescope Module																																																													
K	2005	(KE)DHS	Body	Vehicle Theft Deterrent																																																													
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																													
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																													
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																													
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																													
K	2005	(KF)DTS	Body	Amplifier (Bose)																																																													
K	2005	(KF)DTS	Body	CD Changer																																																													
K	2005	(KF)DTS	Body	Dash Integration Module																																																													
K	2005	(KF)DTS	Body	Digital Radio Receiver																																																													
K	2005	(KF)DTS	Body	Driver Door Switch																																																													
K	2005	(KF)DTS	Body	Driver Door Module																																																													
K	2005	(KF)DTS	Body	Passenger Door Module																																																													
K	2005	(KF)DTS	Body	Left Rear Door Module																																																													
K	2005	(KF)DTS	Body	Right Rear Door Module																																																													
K	2005	(KF)DTS	Body	Instrument Panel Cluster																																																													
K	2005	(KF)DTS	Body	Instrument Panel Module																																																													
K	2005	(KF)DTS	Body	Memory Seat Module																																																													
K	2005	(KF)DTS	Body	Navigation Radio																																																													
K	2005	(KF)DTS	Body	Radio																																																													
K	2005	(KF)DTS	Body	Rear Climate Control Panel																																																													
K	2005	(KF)DTS	Body	Rear Integration Module																																																													
K	2005	(KF)DTS	Body	Remote Function Actuation																																																													
K	2005	(KF)DTS	Body	Supplemental Inflatable Restraint																																																													
K	2005	(KF)DTS	Body	Tilt Telescope Module																																																													
K	2005	(KF)DTS	Body	Vehicle Theft Deterrent																																																													
K	2006	ALL	Powertrain	Engine Control Module																																																														
K	2006	ALL	Powertrain	Automatic Transaxle																																																														
K	2006	ALL	Chassis	Antilock Brake System																																																														
K	2006	ALL	Body	Amplifier (Bose)																																																														
K	2006	ALL	Body	Aux. HVAC Control Module																																																														
K	2006	ALL	Body	Body Control Module																																																														
K	2006	ALL	Body	Digital Radio Receiver																																																														
K	2006	ALL	Body	Distance Sensing Cruise Control																																																														
K	2006	ALL	Body	Driver Door Switch																																																														
K	2006	ALL	Body	Driver Position Module																																																														
K	2006	ALL	Body	HVAC Control Module																																																														
K	2006	ALL	Body	Instrument Panel Cluster																																																														
K	2006	ALL	Body	Park Assist Module																																																														

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2006	ALL	Body	Passenger Door Switch																																																											
K	2006	ALL	Body	Passenger Presence System																																																											
K	2006	ALL	Body	Radio																																																											
K	2006	ALL	Body	Rear Heated Seat Module																																																											
K	2006	ALL	Body	Remote Control Door Lock Receiver																																																											
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2006	ALL	Body	Theft Deterrent Module																																																											
K	2006	ALL	Body	TV Antenna Module																																																											
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																											
K	2007	ALL	Powertrain	Engine Control Module																																																											
K	2007	ALL	Powertrain	Transmission Control Module																																																											
K	2007	ALL	Chassis	Electronic Brake Control Module																																																											
K	2007	ALL	Body	Amplifier (Bose)																																																											
K	2007	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																											
K	2007	ALL	Body	Body Control Module																																																											
K	2007	ALL	Body	Digital Radio Receiver																																																											
K	2007	ALL	Body	Distance Sensing Cruise Control																																																											
K	2007	ALL	Body	Driver Door Switch																																																											
K	2007	ALL	Body	Driver Position Module																																																											
K	2007	ALL	Body	CJ2 Dual Zone HVAC Auto																																																											
K	2007	ALL	Body	CJ4 Tri Zone HVAC Auto																																																											
K	2007	ALL	Body	Inside Rear View Mirror Module																																																											
K	2007	ALL	Body	Instrument Panel Cluster																																																											
K	2007	ALL	Body	Park Assist Module																																																											
K	2007	ALL	Body	Passenger Door Switch																																																											
K	2007	ALL	Body	Passenger Presence System																																																											
K	2007	ALL	Body	Radio																																																											
K	2007	ALL	Body	Rear Heated Seat Module																																																											
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2007	ALL	Body	Theft Deterrent Module																																																											
K	2007	ALL	Body	TV Antenna Module																																																											
K	2007	ALL	Body	Vehicle Comm. Interface Module																																																											
K	2008	ALL	Powertrain	Engine Control Module																																																											
K	2008	ALL	Powertrain	Transmission Control Module																																																											
K	2008	ALL	Chassis	Electronic Brake Control Module																																																											
K	2008	ALL	Body	Amplifier (Bose)																																																											
K	2008	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																											
K	2008	ALL	Body	Body Control Module																																																											
K	2008	ALL	Body	Digital Radio Receiver																																																											
K	2008	ALL	Body	Distance Sensing Cruise Control																																																											
K	2008	ALL	Body	Driver Door Switch																																																											
K	2008	ALL	Body	Driver Position Module																																																											
K	2008	ALL	Body	CJ2 Dual Zone HVAC Auto																																																											
K	2008	ALL	Body	CJ4 Tri Zone HVAC Auto																																																											
K	2008	ALL	Body	Inside Rear View Mirror Module																																																											
K	2008	ALL	Body	Instrument Panel Cluster																																																											
K	2008	ALL	Body	Left Side Object Detection Module																																																											
K	2008	ALL	Body	Park Assist Module																																																											
K	2008	ALL	Body	Passenger Door Switch																																																											
K	2008	ALL	Body	Passenger Presence System																																																											
K	2008	ALL	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2008	ALL	Body	Rear Heated Seat Module																																																											
K	2008	ALL	Body	Right Side Object Detection Module																																																												
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2008	ALL	Body	Theft Deterrent Module																																																												
K	2008	ALL	Body	TV Antenna Module																																																												
K	2008	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2008	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																												
K	2009	ALL	Powertrain	Engine Control Module																																																												
K	2009	ALL	Powertrain	Transmission Control Module																																																												
K	2009	ALL	Chassis	Electronic Brake Control Module																																																												
K	2009	ALL	Body	Amplifier (Bose)																																																												
K	2009	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																												
K	2009	ALL	Body	Body Control Module																																																												
K	2009	ALL	Body	Digital Radio Receiver																																																												
K	2009	ALL	Body	Distance Sensing Cruise Control																																																												
K	2009	ALL	Body	Driver Door Switch																																																												
K	2009	ALL	Body	Driver Position Module																																																												
K	2009	ALL	Body	CJ2 Dual Zone HVAC Auto																																																												
K	2009	ALL	Body	CJ4 Tri Zone HVAC Auto																																																												
K	2009	ALL	Body	Inside Rear View Mirror Module																																																												
K	2009	ALL	Body	Instrument Panel Cluster																																																												
K	2009	ALL	Body	Left Side Object Detection Module																																																												
K	2009	ALL	Body	Park Assist Module																																																												
K	2009	ALL	Body	Passenger Door Switch																																																												
K	2009	ALL	Body	Passenger Presence System																																																												
K	2009	ALL	Body	Radio																																																												
K	2009	ALL	Body	Rear Heated Seat Module																																																												
K	2009	ALL	Body	Right Side Object Detection Module																																																												
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2009	ALL	Body	Theft Deterrent Module																																																												
K	2009	ALL	Body	TV Antenna Module																																																												
K	2009	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2009	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2009	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																												
K	2010	ALL	Powertrain	Engine Control Module																																																												
K	2010	ALL	Powertrain	Transmission Control Module																																																												
K	2010	ALL	Chassis	Electronic Brake Control Module																																																												
K	2010	ALL	Body	Amplifier (Bose)																																																												
K	2010	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																												
K	2010	ALL	Body	Body Control Module																																																												
K	2010	ALL	Body	Digital Radio Receiver																																																												
K	2010	ALL	Body	Distance Sensing Cruise Control																																																												
K	2010	ALL	Body	Driver Door Switch																																																												
K	2010	ALL	Body	Driver Position Module																																																												
K	2010	ALL	Body	CJ2 Dual Zone HVAC Auto																																																												
K	2010	ALL	Body	CJ4 Tri Zone HVAC Auto																																																												
K	2010	ALL	Body	Inside Rear View Mirror Module																																																												
K	2010	ALL	Body	Instrument Panel Cluster																																																												
K	2010	ALL	Body	Left Side Object Detection Module																																																												
K	2010	ALL	Body	Park Assist Module																																																												
K	2010	ALL	Body	Passenger Door Switch																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2010	ALL	Body	Passenger Presence System																																																											
K	2010	ALL	Body	Radio																																																											
K	2010	ALL	Body	Rear Heated Seat Module																																																												
K	2010	ALL	Body	Right Side Object Detection Module																																																												
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2010	ALL	Body	Theft Deterrent Module																																																												
K	2010	ALL	Body	TV Antenna Module																																																												
K	2010	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2010	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																												
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Engine Control Module																																																												
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Transmission Control Module																																																												
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Engine Control Module																																																												
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Transmission Control Module																																																												
K	2011	ALL	Chassis	Electronic Brake Control Module																																																												
K	2011	ALL	Body	Amplifier (Bose)																																																												
K	2011	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																												
K	2011	ALL	Body	Body Control Module																																																												
K	2011	ALL	Body	Digital Radio Receiver																																																												
K	2011	ALL	Body	Distance Sensing Cruise Control																																																												
K	2011	ALL	Body	Driver Door Switch																																																												
K	2011	ALL	Body	Driver Position Module																																																												
K	2011	ALL	Body	CJ2 Dual Zone HVAC Auto																																																												
K	2011	ALL	Body	CJ4 Tri Zone HVAC Auto																																																												
K	2011	ALL	Body	Inside Rear View Mirror Module																																																												
K	2011	ALL	Body	Instrument Panel Cluster																																																												
K	2011	ALL	Body	Left Side Object Detection Module																																																												
K	2011	ALL	Body	Park Assist Module																																																												
K	2011	ALL	Body	Passenger Door Switch																																																												
K	2011	ALL	Body	Passenger Presence System																																																												
K	2011	ALL	Body	Radio																																																												
K	2011	ALL	Body	Rear Heated Seat Module																																																												
K	2011	ALL	Body	Right Side Object Detection Module																																																												
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2011	ALL	Body	Theft Deterrent Module																																																												
K	2011	ALL	Body	TV Antenna Module																																																												
K	2011	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2011	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																												
K	2016	CT6	Powertrain	(X) 2.0L LTG Engine Control Module																																																												
K	2016	CT6	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
K	2016	CT6	Powertrain	(6) 3.0L LGW Engine Control Module																																																												
K	2016	CT6	Powertrain	(6) 3.0L LGW Transmission Control Module																																																												
K	2016	CT6	Powertrain	(S) 3.6L LGX Engine Control Module																																																												
K	2016	CT6	Powertrain	(S) 3.6L LGX Transmission Control Module																																																												
K	2016	CT6	Powertrain	Transfer Case Control Module																																																												
K	2016	CT6	Chassis	Electronic Brake Control Module																																																												
K	2016	CT6	Chassis	Brake Booster Control Module																																																												
K	2016	CT6	Chassis	Power Steering Control Module																																																												
K	2016	CT6	Chassis	Rear Wheel Steering Control Module																																																												
K	2016	CT6	Chassis	Suspension Control Module																																																												
K	2016	CT6	Body	Body Control Module																																																												
K	2016	CT6	Body	Serial Data Gateway Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2016	CT6	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2016	CT6	Body	Passenger Presence Module																																																													
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Left																																																												
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Right																																																												
K	2016	CT6	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
K	2016	CT6	Body	Instrument Cluster Full Screen Display (UDV)																																																												
K	2016	CT6	Body	Radio Controls																																																												
K	2016	CT6	Body	HVAC Controls																																																												
K	2016	CT6	Body	Active Safety Control Module																																																												
K	2016	CT6	Body	Video Processing Control Module																																																												
K	2016	CT6	Body	Headlamp Control Module																																																												
K	2016	CT6	Body	Trailer Interface Control Module																																																												
K	2016	CT6	Body	Radio																																																												
K	2016	CT6	Body	Amplifier																																																												
K	2016	CT6	Body	Infotainment Control Touchpad																																																												
K	2016	CT6	Body	Human Machine Interface Control Module																																																												
K	2016	CT6	Body	Navigation Control Module																																																												
K	2016	CT6	Body	Telematics Communication Interface Control Module																																																												
K	2016	CT6	Body	HVAC Control Module																																																												
K	2016	CT6	Body	Liftgate Control Module																																																												
K	2016	CT6	Body	Seat Memory Control Module - Passenger																																																												
K	2016	CT6	Body	Seat Memory Control Module - Left Rear																																																												
K	2016	CT6	Body	Seat Memory Control Module - Driver																																																												
K	2016	CT6	Body	Seat Memory Control Module - Right Rear																																																												
K	2016	CT6	Body	Keyless Entry Control Module																																																												
K	2016	CT6	Body	Left Side Object Detection Control Module																																																												
K	2016	CT6	Body	Parking Assist Control Module																																																												
K	2016	CT6	Body	Frontview Camera Module																																																												
K	2016	CT6	Body	Long Range Radar Sensor Module																																																												
K	2016	CT6	Body	Left Front Short Range Radar Sensor Module																																																												
K	2016	CT6	Body	Right Front Short Range Radar Sensor Module																																																												
K	2016	CT6	Body	Rear Short Range Radar Sensor Module																																																												
K	2016	CT6	Body	Night Vision Camera Control Module																																																												
R	2014	ELR	Powertrain	Engine Control Module																																																												
R	2014	ELR	Powertrain	Trasmission Control Module																																																												
R	2014	ELR	Powertrain	Chassis Control Module																																																												
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module																																																												
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																												
R	2014	ELR	Powertrain	Drive Motor Control Module 1																																																												
R	2014	ELR	Powertrain	Drive Motor Control Module 2																																																												
R	2014	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2014	ELR	Chassis	Electronic Brake Control Module																																																												
R	2014	ELR	Chassis	Distance Sensing Cruise Control Module																																																												
R	2014	ELR	Chassis	Parking Brake Control Module																																																												
R	2014	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																												
R	2014	ELR	Chassis	Power Steering Control Module																																																												
R	2014	ELR	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2014	ELR	Chassis	Suspension Control Module																																																												
R	2014	ELR	Body	Body Control Module																																																												
R	2014	ELR	Body	Pedestrian Impact Detection Module																																																												
R	2014	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2014	ELR	Body	Passenger Presence Module																																																										
R	2014	ELR	Body	Instrument Cluster																																																										
R	2014	ELR	Body	Radio/HVAC Control																																																										
R	2014	ELR	Body	Radio																																																										
R	2014	ELR	Body	Amplifier																																																										
R	2014	ELR	Body	Human Machine Interface Control Module																																																										
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	ELR	Body	HVAC Control Module																																																										
R	2014	ELR	Body	Electric A/C Compressor Control Module																																																										
R	2014	ELR	Body	Coolant Heater Control Module																																																										
R	2014	ELR	Body	Seat Memory Control Module - Driver																																																										
R	2014	ELR	Body	Keyless Entry Control Module																																																										
R	2014	ELR	Body	Right Side Object Detection Control Module																																																										
R	2014	ELR	Body	Left Side Object Detection Control Module																																																										
R	2014	ELR	Body	Parking Assist Control Module																																																										
R	2014	ELR	Body	Frontview Camera Module																																																										
R	2014	ELR	Body	Steering Column Lock Control Module																																																										
R	2014	ELR	Body	Battery Charger Control Module																																																										
R	2014	ELR	Body	Battery Energy Control Module																																																										
R	2015	ELR	Powertrain	Engine Control Module																																																										
R	2015	ELR	Powertrain	Trasmission Control Module																																																										
R	2015	ELR	Powertrain	Chassis Control Module																																																										
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module																																																										
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2015	ELR	Powertrain	Drive Motor Control Module 1																																																										
R	2015	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2015	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2015	ELR	Chassis	Electronic Brake Control Module																																																										
R	2015	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2015	ELR	Chassis	Parking Brake Control Module																																																										
R	2015	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2015	ELR	Chassis	Power Steering Control Module																																																										
R	2015	ELR	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2015	ELR	Chassis	Suspension Control Module																																																										
R	2015	ELR	Body	Body Control Module																																																										
R	2015	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2015	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	ELR	Body	Passenger Presence Module																																																										
R	2015	ELR	Body	Instrument Cluster																																																										
R	2015	ELR	Body	Radio/HVAC Control																																																										
R	2015	ELR	Body	Headlamp Control Module																																																										
R	2015	ELR	Body	Radio																																																										
R	2015	ELR	Body	Amplifier																																																										
R	2015	ELR	Body	Human Machine Interface Control Module																																																										
R	2015	ELR	Body	Telematics Communication Interface Control Module																																																										
R	2015	ELR	Body	HVAC Control Module																																																										
R	2015	ELR	Body	Electric A/C Compressor Control Module																																																										
R	2015	ELR	Body	Coolant Heater Control Module																																																										
R	2015	ELR	Body	Seat Memory Control Module - Driver																																																										
R	2015	ELR	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2015	ELR	Body	Right Side Object Detection Control Module																																																											
R	2015	ELR	Body	Left Side Object Detection Control Module																																																												
R	2015	ELR	Body	Parking Assist Control Module																																																												
R	2015	ELR	Body	Frontview Camera Module																																																												
R	2015	ELR	Body	Steering Column Lock Control Module																																																												
R	2015	ELR	Body	Battery Charger Control Module																																																												
R	2015	ELR	Body	Battery Energy Control Module																																																												
R	2016	ELR	Powertrain	Engine Control Module																																																												
R	2016	ELR	Powertrain	Trasmission Control Module																																																												
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module																																																												
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																												
R	2016	ELR	Powertrain	Drive Motor Control Module 1																																																												
R	2016	ELR	Powertrain	Drive Motor Control Module 2																																																												
R	2016	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2016	ELR	Chassis	Electronic Brake Control Module																																																												
R	2016	ELR	Chassis	Distance Sensing Cruise Control Module																																																												
R	2016	ELR	Chassis	Parking Brake Control Module																																																												
R	2016	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																												
R	2016	ELR	Chassis	Power Steering Control Module																																																												
R	2016	ELR	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2016	ELR	Chassis	Suspension Control Module																																																												
R	2016	ELR	Body	Body Control Module																																																												
R	2016	ELR	Body	Pedestrian Impact Detection Module																																																												
R	2016	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2016	ELR	Body	Passenger Presence Module																																																												
R	2016	ELR	Body	Instrument Cluster																																																												
R	2016	ELR	Body	Radio/HVAC Control																																																												
R	2016	ELR	Body	Headlamp Control Module																																																												
R	2016	ELR	Body	Radio																																																												
R	2016	ELR	Body	Amplifier																																																												
R	2016	ELR	Body	Human Machine Interface Control Module																																																												
R	2016	ELR	Body	Telematics Communication Interface Control Module																																																												
R	2016	ELR	Body	HVAC Control Module																																																												
R	2016	ELR	Body	Electric A/C Compressor Control Module																																																												
R	2016	ELR	Body	Coolant Heater Control Module																																																												
R	2016	ELR	Body	Seat Memory Control Module - Driver																																																												
R	2016	ELR	Body	Keyless Entry Control Module																																																												
R	2016	ELR	Body	Left Side Object Detection Control Module																																																												
R	2016	ELR	Body	Parking Assist Control Module																																																												
R	2016	ELR	Body	Frontview Camera Module																																																												
R	2016	ELR	Body	Steering Column Lock Control Module																																																												
R	2016	ELR	Body	Battery Charger Control Module																																																												
R	2016	ELR	Body	Battery Energy Control Module																																																												
Y	2004	ALL	Powertrain	Engine Control Module																																																												
Y	2004	ALL	Powertrain	Automatic Transmission																																																												
Y	2004	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2004	ALL	Chassis	Electronic Suspension Control																																																												
Y	2004	ALL	Chassis	Steering Wheel and Column																																																												
Y	2004	ALL	Body	Amplifier (Bose)																																																												
Y	2004	ALL	Body	Body Control Module																																																												
Y	2004	ALL	Body	CD Changer																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Y	2004	ALL	Body	Digital Radio Receiver																																																										
Y	2004	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2004	ALL	Body	Driver Door Module																																																										
Y	2004	ALL	Body	Driver Door Switch																																																										
Y	2004	ALL	Body	Driver Position Module																																																										
Y	2004	ALL	Body	Folding Top Module																																																										
Y	2004	ALL	Body	Head Up Display																																																										
Y	2004	ALL	Body	HVAC Control Module																																																										
Y	2004	ALL	Body	Instrument Panel Cluster																																																										
Y	2004	ALL	Body	Navigation Radio																																																										
Y	2004	ALL	Body	Passenger Door Module																																																										
Y	2004	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2004	ALL	Body	Steering Column Lock Module																																																										
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2005	ALL	Powertrain	Engine Control Module																																																										
Y	2005	ALL	Powertrain	Automatic Transmission																																																										
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2005	ALL	Chassis	Electronic Suspension Control																																																										
Y	2005	ALL	Chassis	Steering Wheel and Column																																																										
Y	2005	ALL	Body	Amplifier (Bose)																																																										
Y	2005	ALL	Body	Body Control Module																																																										
Y	2005	ALL	Body	CD Changer																																																										
Y	2005	ALL	Body	Digital Radio Receiver																																																										
Y	2005	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2005	ALL	Body	Driver Door Module																																																										
Y	2005	ALL	Body	Driver Door Switch																																																										
Y	2005	ALL	Body	Driver Position Module																																																										
Y	2005	ALL	Body	Folding Top Module																																																										
Y	2005	ALL	Body	Head Up Display																																																										
Y	2005	ALL	Body	HVAC Control Module																																																										
Y	2005	ALL	Body	Instrument Panel Cluster																																																										
Y	2005	ALL	Body	Navigation Radio																																																										
Y	2005	ALL	Body	Passenger Door Module																																																										
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2005	ALL	Body	Steering Column Lock Module																																																										
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2006	(YV)XLR	Powertrain	Engine Control Module																																																										
Y	2006	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																										
Y	2006	(YV)XLR	Powertrain	Automatic Transmission																																																										
Y	2006	(YV)XLR	Chassis	Electronic Brake Control Module																																																										
Y	2006	(YV)XLR	Chassis	Electronic Suspension Control																																																										
Y	2006	(YV)XLR	Chassis	Steering Wheel and Column																																																										
Y	2006	(YV)XLR	Body	Amplifier (Bose)																																																										
Y	2006	(YV)XLR	Body	Body Control Module																																																										
Y	2006	(YV)XLR	Body	CD Changer																																																										
Y	2006	(YV)XLR	Body	Digital Radio Receiver																																																										
Y	2006	(YV)XLR	Body	Distance Sensing Cruise Control																																																										
Y	2006	(YV)XLR	Body	Driver Door Module																																																										
Y	2006	(YV)XLR	Body	Driver Door Switch																																																										
Y	2006	(YV)XLR	Body	Driver Position Module																																																										
Y	2006	(YV)XLR	Body	Folding Top Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Y	2006	(YV)XLR	Body	Headlamp Control Module																																																											
Y	2006	(YV)XLR	Body	Head Up Display																																																												
Y	2006	(YV)XLR	Body	HVAC Control Module																																																												
Y	2006	(YV)XLR	Body	Instrument Panel Cluster																																																												
Y	2006	(YV)XLR	Body	Navigation Radio																																																												
Y	2006	(YV)XLR	Body	Passenger Door Module																																																												
Y	2006	(YV)XLR	Body	Remote Control Door Lock Receiver																																																												
Y	2006	(YV)XLR	Body	Steering Column Lock Module																																																												
Y	2006	(YV)XLR	Body	Supplemental Inflatable Restraint																																																												
Y	2006	(YX)XLR-V	Powertrain	Engine Control Module																																																												
Y	2006	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																												
Y	2006	(YX)XLR-V	Powertrain	Automatic Transmission																																																												
Y	2006	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																												
Y	2006	(YX)XLR-V	Chassis	Electronic Suspension Control																																																												
Y	2006	(YX)XLR-V	Chassis	Steering Wheel and Column																																																												
Y	2006	(YX)XLR-V	Body	Amplifier (Bose)																																																												
Y	2006	(YX)XLR-V	Body	Body Control Module																																																												
Y	2006	(YX)XLR-V	Body	CD Changer																																																												
Y	2006	(YX)XLR-V	Body	Digital Radio Receiver																																																												
Y	2006	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																												
Y	2006	(YX)XLR-V	Body	Driver Door Module																																																												
Y	2006	(YX)XLR-V	Body	Driver Door Switch																																																												
Y	2006	(YX)XLR-V	Body	Driver Position Module																																																												
Y	2006	(YX)XLR-V	Body	Folding Top Module																																																												
Y	2006	(YX)XLR-V	Body	Headlamp Control Module																																																												
Y	2006	(YX)XLR-V	Body	Head Up Display																																																												
Y	2006	(YX)XLR-V	Body	HVAC Control Module																																																												
Y	2006	(YX)XLR-V	Body	Instrument Panel Cluster																																																												
Y	2006	(YX)XLR-V	Body	Navigation Radio																																																												
Y	2006	(YX)XLR-V	Body	Passenger Door Module																																																												
Y	2006	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																																												
Y	2006	(YX)XLR-V	Body	Steering Column Lock Module																																																												
Y	2006	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																												
Y	2007	(YV)XLR	Powertrain	Engine Control Module																																																												
Y	2007	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																												
Y	2007	(YV)XLR	Powertrain	Transmission Control Module																																																												
Y	2007	(YV)XLR	Chassis	Electronic Brake Control Module																																																												
Y	2007	(YV)XLR	Chassis	Electronic Suspension Control																																																												
Y	2007	(YV)XLR	Body	Amplifier (Bose)																																																												
Y	2007	(YV)XLR	Body	Body Control Module																																																												
Y	2007	(YV)XLR	Body	CD Changer																																																												
Y	2007	(YV)XLR	Body	Digital Radio Receiver																																																												
Y	2007	(YV)XLR	Body	Distance Sensing Cruise Control																																																												
Y	2007	(YV)XLR	Body	Driver Door Module																																																												
Y	2007	(YV)XLR	Body	Driver Door Switch																																																												
Y	2007	(YV)XLR	Body	Driver Position Module																																																												
Y	2007	(YV)XLR	Body	Folding Top Module																																																												
Y	2007	(YV)XLR	Body	Headlamp Control Module																																																												
Y	2007	(YV)XLR	Body	Head Up Display																																																												
Y	2007	(YV)XLR	Body	HVAC Control Module																																																												
Y	2007	(YV)XLR	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Y	2007	(YV)XLR	Body	Navigation Radio																																																										
Y	2007	(YV)XLR	Body	Passenger Door Module																																																										
Y	2007	(YV)XLR	Body	Remote Control Door Lock Receiver																																																										
Y	2007	(YV)XLR	Body	Steering Column Lock Module																																																										
Y	2007	(YV)XLR	Body	Supplemental Inflatable Restraint																																																										
Y	2007	(YX)XLR-V	Powertrain	Engine Control Module																																																										
Y	2007	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	(YX)XLR-V	Powertrain	Transmission Control Module																																																										
Y	2007	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																										
Y	2007	(YX)XLR-V	Chassis	Electronic Suspension Control																																																										
Y	2007	(YX)XLR-V	Body	Amplifier (Bose)																																																										
Y	2007	(YX)XLR-V	Body	Body Control Module																																																										
Y	2007	(YX)XLR-V	Body	CD Changer																																																										
Y	2007	(YX)XLR-V	Body	Digital Radio Receiver																																																										
Y	2007	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																										
Y	2007	(YX)XLR-V	Body	Driver Door Module																																																										
Y	2007	(YX)XLR-V	Body	Driver Door Switch																																																										
Y	2007	(YX)XLR-V	Body	Driver Position Module																																																										
Y	2007	(YX)XLR-V	Body	Folding Top Module																																																										
Y	2007	(YX)XLR-V	Body	Headlamp Control Module																																																										
Y	2007	(YX)XLR-V	Body	Head Up Display																																																										
Y	2007	(YX)XLR-V	Body	HVAC Control Module																																																										
Y	2007	(YX)XLR-V	Body	Instrument Panel Cluster																																																										
Y	2007	(YX)XLR-V	Body	Navigation Radio																																																										
Y	2007	(YX)XLR-V	Body	Passenger Door Module																																																										
Y	2007	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																																										
Y	2007	(YX)XLR-V	Body	Steering Column Lock Module																																																										
Y	2007	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																										
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2008	ALL	Chassis	Electronic Suspension Control																																																										
Y	2008	ALL	Body	Amplifier (Bose)																																																										
Y	2008	ALL	Body	Body Control Module																																																										
Y	2008	ALL	Body	CD Changer																																																										
Y	2008	ALL	Body	Digital Radio Receiver																																																										
Y	2008	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2008	ALL	Body	Driver Door Module																																																										
Y	2008	ALL	Body	Driver Door Switch																																																										
Y	2008	ALL	Body	Driver Position Module																																																										
Y	2008	ALL	Body	Folding Top Module																																																										
Y	2008	ALL	Body	Headlamp Control Module																																																										
Y	2008	ALL	Body	Head Up Display																																																										
Y	2008	ALL	Body	HVAC Control Module																																																										
Y	2008	ALL	Body	Instrument Panel Cluster																																																										
Y	2008	ALL	Body	Navigation Radio																																																										
Y	2008	ALL	Body	Passenger Door Module																																																										
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Y	2008	ALL	Body	Steering Column Lock Module																																																										
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Body	Vehicle Comm. Interface Module																																																										
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																										
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
Y	2009	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2009	ALL	Chassis	Electronic Suspension Control																																																										
Y	2009	ALL	Body	Amplifier (Bose)																																																										
Y	2009	ALL	Body	Body Control Module																																																										
Y	2009	ALL	Body	CD Changer																																																										
Y	2009	ALL	Body	Digital Radio Receiver																																																										
Y	2009	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2009	ALL	Body	Driver Door Module																																																										
Y	2009	ALL	Body	Driver Door Switch																																																										
Y	2009	ALL	Body	Driver Position Module																																																										
Y	2009	ALL	Body	Folding Top Module																																																										
Y	2009	ALL	Body	Headlamp Control Module																																																										
Y	2009	ALL	Body	Head Up Display																																																										
Y	2009	ALL	Body	HVAC Control Module																																																										
Y	2009	ALL	Body	Instrument Panel Cluster																																																										
Y	2009	ALL	Body	Navigation Radio																																																										
Y	2009	ALL	Body	Passenger Door Module																																																										
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2009	ALL	Body	Steering Column Lock Module																																																										
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
1	2013	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2013	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2013	XTS	Powertrain	Fuel Pump Control Module																																																										
1	2013	XTS	Powertrain	Rear Differential Clutch Control Module																																																										
1	2013	XTS	Chassis	Electronic Brake Control Module																																																										
1	2013	XTS	Chassis	Parking Brake Control Module																																																										
1	2013	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2013	XTS	Chassis	Power Steering Control Module																																																										
1	2013	XTS	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2013	XTS	Chassis	Suspension Control Module																																																										
1	2013	XTS	Body	Body Control Module																																																										
1	2013	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2013	XTS	Body	Passenger Presence Module																																																										
1	2013	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
1	2013	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
1	2013	XTS	Body	Radio/HVAC Control																																																										
1	2013	XTS	Body	Active Safety Control Module																																																										
1	2013	XTS	Body	Headlamp Control Module																																																										
1	2013	XTS	Body	Radio																																																										
1	2013	XTS	Body	Amplifier																																																										
1	2013	XTS	Body	Human Machine Interface Control Module																																																										
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2013	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2013	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
1	2013	XTS	Body	Seat Memory Control Module																																																										
1	2013	XTS	Body	Keyless Entry Control Module																																																										
1	2013	XTS	Body	Right Side Object Detection Control Module																																																										
1	2013	XTS	Body	Left Side Object Detection Control Module																																																										
1	2013	XTS	Body	Parking Assist Control Module																																																										
1	2013	XTS	Body	Frontview Camera Module																																																										
1	2013	XTS	Body	Long Range Radar Sensor Module																																																										
1	2013	XTS	Body	Left Front Short Range Radar Sensor Module																																																										
1	2013	XTS	Body	Right Front Short Range Radar Sensor Module																																																										
1	2013	XTS	Body	Rear Short Range Radar Sensor Module																																																										
1	2014	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
1	2014	XTS	Powertrain	(8) 3.6L LF3 Chassis Control Module																																																										
1	2014	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
1	2014	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2014	XTS	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
1	2014	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2014	XTS	Powertrain	Rear Differential Clutch Control Module																																																										
1	2014	XTS	Chassis	Electronic Brake Control Module																																																										
1	2014	XTS	Chassis	Parking Brake Control Module																																																										
1	2014	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2014	XTS	Chassis	Power Steering Control Module																																																										
1	2014	XTS	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2014	XTS	Chassis	Suspension Control Module																																																										
1	2014	XTS	Body	Body Control Module																																																										
1	2014	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	XTS	Body	Passenger Presence Module																																																										
1	2014	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
1	2014	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
1	2014	XTS	Body	Radio/HVAC Control																																																										
1	2014	XTS	Body	Active Safety Control Module																																																										
1	2014	XTS	Body	Headlamp Control Module																																																										
1	2014	XTS	Body	Radio																																																										
1	2014	XTS	Body	Amplifier																																																										
1	2014	XTS	Body	Media Disc Player																																																										
1	2014	XTS	Body	Human Machine Interface Control Module																																																										
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
1	2014	XTS	Body	Seat Memory Control Module - Passenger																																																										
1	2014	XTS	Body	Seat Memory Control Module - Driver																																																										
1	2014	XTS	Body	Keyless Entry Control Module																																																										
1	2014	XTS	Body	Right Side Object Detection Control Module																																																										
1	2014	XTS	Body	Left Side Object Detection Control Module																																																										
1	2014	XTS	Body	Parking Assist Control Module																																																										
1	2014	XTS	Body	Frontview Camera Module																																																										
1	2014	XTS	Body	Long Range Radar Sensor Module																																																										
1	2014	XTS	Body	Left Front Short Range Radar Sensor Module																																																										
1	2014	XTS	Body	Right Front Short Range Radar Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2014	XTS	Body	Rear Short Range Radar Sensor Module																																																										
1	2015	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
1	2015	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
1	2015	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2015	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2015	XTS	Powertrain	Chassis Control Module																																																										
1	2015	XTS	Powertrain	Rear Differential Clutch Control Module																																																										
1	2015	XTS	Chassis	Electronic Brake Control Module																																																										
1	2015	XTS	Chassis	Parking Brake Control Module																																																										
1	2015	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	XTS	Chassis	Power Steering Control Module																																																										
1	2015	XTS	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	XTS	Chassis	Suspension Control Module																																																										
1	2015	XTS	Body	Body Control Module																																																										
1	2015	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	XTS	Body	Passenger Presence Module																																																										
1	2015	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
1	2015	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
1	2015	XTS	Body	Radio/HVAC Control																																																										
1	2015	XTS	Body	Active Safety Control Module																																																										
1	2015	XTS	Body	Radio																																																										
1	2015	XTS	Body	Amplifier																																																										
1	2015	XTS	Body	Media Disc Player																																																										
1	2015	XTS	Body	Human Machine Interface Control Module																																																										
1	2015	XTS	Body	Telematics Communication Interface Control Module																																																										
1	2015	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2015	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
1	2015	XTS	Body	Seat Memory Control Module - Passenger																																																										
1	2015	XTS	Body	Seat Memory Control Module - Driver																																																										
1	2015	XTS	Body	Keyless Entry Control Module																																																										
1	2015	XTS	Body	Right Side Object Detection Control Module																																																										
1	2015	XTS	Body	Left Side Object Detection Control Module																																																										
1	2015	XTS	Body	Parking Assist Control Module GMLAN																																																										
1	2015	XTS	Body	Parking Assist Control Module DID72History																																																										
1	2015	XTS	Body	Frontview Camera Module																																																										
1	2015	XTS	Body	Long Range Radar Sensor Module																																																										
1	2015	XTS	Body	Left Front Short Range Radar Sensor Module																																																										
1	2015	XTS	Body	Right Front Short Range Radar Sensor Module																																																										
1	2015	XTS	Body	Rear Short Range Radar Sensor Module																																																										
1	2016	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
1	2016	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
1	2016	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2016	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2016	XTS	Powertrain	Chassis Control Module																																																										
1	2016	XTS	Powertrain	Rear Differential Clutch Control Module																																																										
1	2016	XTS	Chassis	Electronic Brake Control Module																																																										
1	2016	XTS	Chassis	Parking Brake Control Module																																																										
1	2016	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2016	XTS	Chassis	Power Steering Control Module																																																										
1	2016	XTS	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	XTS	Chassis	Suspension Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2016	XTS	Body	Body Control Module																																																											
1	2016	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2016	XTS	Body	Passenger Presence Module																																																												
1	2016	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
1	2016	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
1	2016	XTS	Body	Radio/HVAC Control																																																												
1	2016	XTS	Body	Active Safety Control Module																																																												
1	2016	XTS	Body	Video Processing Control Module																																																												
1	2016	XTS	Body	Radio																																																												
1	2016	XTS	Body	Amplifier																																																												
1	2016	XTS	Body	Media Disc Player																																																												
1	2016	XTS	Body	Human Machine Interface Control Module																																																												
1	2016	XTS	Body	Telematics Communication Interface Control Module																																																												
1	2016	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2016	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
1	2016	XTS	Body	Seat Memory Control Module - Passenger																																																												
1	2016	XTS	Body	Seat Memory Control Module - Driver																																																												
1	2016	XTS	Body	Keyless Entry Control Module																																																												
1	2016	XTS	Body	Right Side Object Detection Control Module																																																												
1	2016	XTS	Body	Left Side Object Detection Control Module																																																												
1	2016	XTS	Body	Parking Assist Control Module																																																												
1	2016	XTS	Body	Frontview Camera Module																																																												
1	2016	XTS	Body	Steering Column Lock Control Module																																																												
1	2016	XTS	Body	Long Range Radar Sensor Module																																																												
1	2016	XTS	Body	Left Front Short Range Radar Sensor Module																																																												
1	2016	XTS	Body	Right Front Short Range Radar Sensor Module																																																												
1	2016	XTS	Body	Rear Short Range Radar Sensor Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																									
A	2013	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Fuel Pump and Engine Mount																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2013	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Fuel Pump and Engine Mount																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2013	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Fuel Pump and Engine Mount																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Fuel Pump Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2013	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2013	ATS	Powertrain	Transfer Case Control Module																																																										
A	2013	ATS	Chassis	Electronic Brake Control Module																																																										
A	2013	ATS	Chassis	Parking Brake Control Module																																																										
A	2013	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	ATS	Chassis	Power Steering Control Module																																																										
A	2013	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	ATS	Chassis	Suspension Control Module																																																										
A	2013	ATS	Body	Body Control Module Halogen																																																										
A	2013	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2013	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	ATS	Body	Passenger Presence Module																																																										
A	2013	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2013	ATS	Body	Instrument Cluster																																																										
A	2013	ATS	Body	Radio/HVAC Control																																																										
A	2013	ATS	Body	Active Safety Control Module																																																										
A	2013	ATS	Body	Headlamp Control Module																																																										
A	2013	ATS	Body	Trailer Interface Control Module																																																										
A	2013	ATS	Body	Radio																																																										
A	2013	ATS	Body	Amplifier																																																										
A	2013	ATS	Body	Human Machine Interface Control Module																																																										
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2013	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2013	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2013	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2013	ATS	Body	Seat Memory Control Module																																																										
A	2013	ATS	Body	Keyless Entry Type Without Passive Entry																																																										
A	2013	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
A	2013	ATS	Body	Right Side Object Detection Control Module																																																										
A	2013	ATS	Body	Left Side Object Detection Control Module																																																										
A	2013	ATS	Body	Parking Assist Control Module																																																										
A	2013	ATS	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2013	ATS	Body	Steering Column Lock Control Module																																																									
A	2013	ATS	Body	Long Range Radar Sensor Module																																																										
A	2013	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2013	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2013	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2014	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2014	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2014	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2014	ATS	Powertrain	Transfer Case Control Module																																																										
A	2014	ATS	Chassis	Electronic Brake Control Module																																																										
A	2014	ATS	Chassis	Parking Brake Control Module																																																										
A	2014	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	ATS	Chassis	Power Steering Control Module																																																										
A	2014	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	ATS	Chassis	Suspension Control Module																																																										
A	2014	ATS	Body	Body Control Module Halogen																																																										
A	2014	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2014	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	ATS	Body	Passenger Presence Module																																																										
A	2014	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2014	ATS	Body	Instrument Cluster																																																										
A	2014	ATS	Body	Radio/HVAC Control																																																										
A	2014	ATS	Body	Active Safety Control Module																																																										
A	2014	ATS	Body	Headlamp Control Module																																																										
A	2014	ATS	Body	Trailer Interface Control Module																																																										
A	2014	ATS	Body	Radio																																																										
A	2014	ATS	Body	Amplifier																																																										
A	2014	ATS	Body	Media Disc Player																																																										
A	2014	ATS	Body	Human Machine Interface Control Module																																																										
A	2014	ATS	Body	Navigation Control Module																																																										
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2014	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2014	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2014	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2014	ATS	Body	Seat Memory Control Module - Driver																																																										
A	2014	ATS	Body	Keyless Entry Type Without Passive Entry																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2014	ATS	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
A	2014	ATS	Body	Right Side Object Detection Control Module																																																												
A	2014	ATS	Body	Left Side Object Detection Control Module																																																												
A	2014	ATS	Body	Parking Assist Control Module																																																												
A	2014	ATS	Body	Frontview Camera Module																																																												
A	2014	ATS	Body	Steering Column Lock Control Module																																																												
A	2014	ATS	Body	Long Range Radar Sensor Module																																																												
A	2014	ATS	Body	Left Front Short Range Radar Sensor Module																																																												
A	2014	ATS	Body	Right Front Short Range Radar Sensor Module																																																												
A	2014	ATS	Body	Rear Short Range Radar Sensor Module																																																												
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																												
A	2014	CTS	Powertrain	(X) 2.0L LTG Engine Control Module Maunal Transmission																																																												
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
A	2014	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																													
A	2014	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																												
A	2014	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																												
A	2014	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																												
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
A	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																												
A	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																												
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																												
A	2014	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																												
A	2014	CTS	Powertrain	Transfer Case Control Module																																																												
A	2014	CTS	Chassis	Electronic Brake Control Module																																																												
A	2014	CTS	Chassis	Parking Brake Control Module																																																												
A	2014	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2014	CTS	Chassis	Power Steering Control Module																																																												
A	2014	CTS	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2014	CTS	Chassis	Suspension Control Module																																																												
A	2014	CTS	Body	Body Control Module Headlamp Type Halogen																																																												
A	2014	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
A	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2014	CTS	Body	Passenger Presence Module																																																												
A	2014	CTS	Body	Pedestrian Impact Detection Module																																																												
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Left																																																												
A	2014	CTS	Body	Seat Belt Retractor Motor Module - Right																																																												
A	2014	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
A	2014	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																												
A	2014	CTS	Body	Radio/HVAC Control																																																												
A	2014	CTS	Body	Active Safety Control Module																																																												
A	2014	CTS	Body	Headlamp Control Module																																																												
A	2014	CTS	Body	Trailer Interface Control Module																																																												
A	2014	CTS	Body	Radio																																																												
A	2014	CTS	Body	Amplifier																																																												
A	2014	CTS	Body	Human Machine Interface Control Module																																																												
A	2014	CTS	Body	Navigation Control Module																																																												
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																												
A	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2014	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2014	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2014	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2014	CTS	Body	Keyless Entry Control Module																																																										
A	2014	CTS	Body	Right Side Object Detection Control Module																																																										
A	2014	CTS	Body	Left Side Object Detection Control Module																																																										
A	2014	CTS	Body	Parking Assist Control Module																																																										
A	2014	CTS	Body	Frontview Camera Module																																																										
A	2014	CTS	Body	Steering Column Lock Control Module																																																										
A	2014	CTS	Body	Long Range Radar Sensor Module																																																										
A	2014	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2014	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2014	CTS	Body	Rear Short Range Radar Sensor Module																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Active Grile Air Shutter																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2015	ATS	Powertrain	Transfer Case Control Module																																																										
A	2015	ATS	Chassis	Electronic Brake Control Module																																																										
A	2015	ATS	Chassis	Parking Brake Control Module																																																										
A	2015	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	ATS	Chassis	Power Steering Control Module																																																										
A	2015	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	ATS	Chassis	Suspension Control Module																																																										
A	2015	ATS	Body	Body Control Module Halogen																																																										
A	2015	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2015	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	ATS	Body	Passenger Presence Module																																																										
A	2015	ATS	Body	Pedestrian Impact Detection Module																																																										
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2015	ATS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2015	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2015	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2015	ATS	Body	Radio/HVAC Control																																																										
A	2015	ATS	Body	Active Safety Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2015	ATS	Body	Headlamp Control Module																																																										
A	2015	ATS	Body	Trailer Interface Control Module																																																											
A	2015	ATS	Body	Radio																																																										
A	2015	ATS	Body	Amplifier																																																										
A	2015	ATS	Body	Media Disc Player																																																										
A	2015	ATS	Body	Human Machine Interface Control Module																																																										
A	2015	ATS	Body	Navigation Control Module																																																										
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2015	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2015	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2015	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2015	ATS	Body	Seat Memory Control Module - Driver																																																										
A	2015	ATS	Body	Keyless Entry Control Module Coupe																																																										
A	2015	ATS	Body	Keyless Entry Control Module Sadan																																																										
A	2015	ATS	Body	Right Side Object Detection Control Module																																																										
A	2015	ATS	Body	Left Side Object Detection Control Module																																																										
A	2015	ATS	Body	Parking Assist Control Module																																																										
A	2015	ATS	Body	Frontview Camera Module																																																										
A	2015	ATS	Body	Steering Column Lock Control Module																																																										
A	2015	ATS	Body	Long Range Radar Sensor Module																																																										
A	2015	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2015	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2015	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Engine Mount																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Engine Mount																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
A	2015	CTS	Powertrain	(8) 3.6L LF3 Rear Differential Clutch Control Module																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Engine Mount																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Fuel Pump and Engine Mount																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Chassis Control Module Active Grile Air Shutter And Engine Mount																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 6 Speed																																																										
A	2015	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module 8 Speed																																																										
A	2015	CTS	Powertrain	Transfer Case Control Module																																																										
A	2015	CTS	Chassis	Electronic Brake Control Module																																																										
A	2015	CTS	Chassis	Parking Brake Control Module																																																										
A	2015	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	CTS	Chassis	Power Steering Control Module																																																										
A	2015	CTS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	CTS	Chassis	Suspension Control Module																																																										
A	2015	CTS	Body	Body Control Module Headlamp Type Halogen																																																										
A	2015	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	CTS	Body	Passenger Presence Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2015	CTS	Body	Pedestrian Impact Detection Module																																																										
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Left																																																										
A	2015	CTS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2015	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2015	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2015	CTS	Body	Active Safety Control Module																																																										
A	2015	CTS	Body	Trailer Interface Control Module																																																										
A	2015	CTS	Body	Radio																																																										
A	2015	CTS	Body	Amplifier																																																										
A	2015	CTS	Body	Human Machine Interface Control Module																																																										
A	2015	CTS	Body	Navigation Control Module																																																										
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2015	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2015	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2015	CTS	Body	Seat Memory Control Module - Driver																																																										
A	2015	CTS	Body	Keyless Entry Control Module																																																										
A	2015	CTS	Body	Right Side Object Detection Control Module																																																										
A	2015	CTS	Body	Left Side Object Detection Control Module																																																										
A	2015	CTS	Body	Parking Assist Control Module																																																										
A	2015	CTS	Body	Frontview Camera Module																																																										
A	2015	CTS	Body	Steering Column Lock Control Module																																																										
A	2015	CTS	Body	Long Range Radar Sensor Module																																																										
A	2015	CTS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2015	CTS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2015	CTS	Body	Rear Short Range Radar Sensor Module																																																										
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
A	2016	ATS	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
A	2016	ATS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
A	2016	ATS	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
A	2016	ATS	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Automatic Transmission																																																										
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Engine Control Module Manual Transmission																																																										
A	2016	ATS	Powertrain	(Y) 3.6L LF4 Transmission Control Module																																																										
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																										
A	2016	ATS	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																										
A	2016	ATS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
A	2016	ATS	Powertrain	Transfer Case Control Module																																																										
A	2016	ATS	Powertrain	Rear Differential Clutch Control Module																																																										
A	2016	ATS	Chassis	Electronic Brake Control Module																																																										
A	2016	ATS	Chassis	Parking Brake Control Module																																																										
A	2016	ATS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2016	ATS	Chassis	Power Steering Control Module																																																										
A	2016	ATS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	ATS	Chassis	Suspension Control Module																																																										
A	2016	ATS	Body	Body Control Module Halogen																																																										
A	2016	ATS	Body	Body Control Module High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2016	ATS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	ATS	Body	Passenger Presence Module																																																										
A	2016	ATS	Body	Pedestrian Impact Detection Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Left																																																									
A	2016	ATS	Body	Seat Belt Retractor Motor Module - Right																																																										
A	2016	ATS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
A	2016	ATS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
A	2016	ATS	Body	Radio/HVAC Control																																																										
A	2016	ATS	Body	Vehicle Performance Data Recorder																																																										
A	2016	ATS	Body	Trailer Interface Control Module																																																										
A	2016	ATS	Body	Radio																																																										
A	2016	ATS	Body	Amplifier																																																										
A	2016	ATS	Body	Rear Audio Control Module																																																										
A	2016	ATS	Body	Media Disc Player																																																										
A	2016	ATS	Body	Human Machine Interface Control Module																																																										
A	2016	ATS	Body	Navigation Control Module																																																										
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2016	ATS	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2016	ATS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
A	2016	ATS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
A	2016	ATS	Body	Seat Memory Control Module - Passenger																																																										
A	2016	ATS	Body	Seat Memory Control Module - Driver																																																										
A	2016	ATS	Body	Keyless Entry Control Module Coupe																																																										
A	2016	ATS	Body	Keyless Entry Control Module Sadan																																																										
A	2016	ATS	Body	Right Side Object Detection Control Module																																																										
A	2016	ATS	Body	Left Side Object Detection Control Module																																																										
A	2016	ATS	Body	Parking Assist Control Module																																																										
A	2016	ATS	Body	Frontview Camera Module																																																										
A	2016	ATS	Body	Steering Column Lock Control Module																																																										
A	2016	ATS	Body	Long Range Radar Sensor Module																																																										
A	2016	ATS	Body	Left Front Short Range Radar Sensor Module																																																										
A	2016	ATS	Body	Right Front Short Range Radar Sensor Module																																																										
A	2016	ATS	Body	Rear Short Range Radar Sensor Module																																																										
A	2016	CTS	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
A	2016	CTS	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
A	2016	CTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
A	2016	CTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
A	2016	CTS	Powertrain	(S) 3.6L LGX Engine Control Module																																																										
A	2016	CTS	Powertrain	(S) 3.6L LGX Transmission Control Module																																																										
A	2016	CTS	Powertrain	(6) 6.2L LT4 Engine Control Module																																																										
A	2016	CTS	Powertrain	(6) 6.2L LT4 Transmission Control Module																																																										
A	2016	CTS	Powertrain	Rear Differential Clutch Control Module																																																										
A	2016	CTS	Powertrain	Transfer Case Control Module																																																										
A	2016	CTS	Chassis	Electronic Brake Control Module																																																										
A	2016	CTS	Chassis	Parking Brake Control Module																																																										
A	2016	CTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2016	CTS	Chassis	Power Steering Control Module																																																										
A	2016	CTS	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	CTS	Chassis	Suspension Control Module																																																										
A	2016	CTS	Body	Body Control Module Headlamp Type Halogen																																																										
A	2016	CTS	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
A	2016	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	CTS	Body	Passenger Presence Module																																																										
A	2016	CTS	Body	Pedestrian Impact Detection Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Left																																																											
A	2016	CTS	Body	Seat Belt Retractor Motor Module - Right																																																											
A	2016	CTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
A	2016	CTS	Body	Instrument Cluster Full Screen Display (UDV)																																																											
A	2016	CTS	Body	Radio/HVAC Control																																																											
A	2016	CTS	Body	Vehicle Performance Data Recorder																																																											
A	2016	CTS	Body	Active Safety Control Module																																																											
A	2016	CTS	Body	Video Processing Control Module																																																											
A	2016	CTS	Body	Trailer Interface Control Module																																																											
A	2016	CTS	Body	Radio																																																											
A	2016	CTS	Body	Amplifier																																																										
A	2016	CTS	Body	Human Machine Interface Control Module																																																											
A	2016	CTS	Body	Navigation Control Module																																																											
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 9.7																																																											
A	2016	CTS	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2016	CTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
A	2016	CTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
A	2016	CTS	Body	Seat Memory Control Module - Passenger																																																											
A	2016	CTS	Body	Seat Memory Control Module - Driver																																																											
A	2016	CTS	Body	Keyless Entry Control Module																																																											
A	2016	CTS	Body	Right Side Object Detection Control Module																																																											
A	2016	CTS	Body	Left Side Object Detection Control Module																																																											
A	2016	CTS	Body	Parking Assist Control Module																																																											
A	2016	CTS	Body	Frontview Camera Module																																																											
A	2016	CTS	Body	Steering Column Lock Control Module																																																											
A	2016	CTS	Body	Long Range Radar Sensor Module																																																											
A	2016	CTS	Body	Left Front Short Range Radar Sensor Module																																																											
A	2016	CTS	Body	Right Front Short Range Radar Sensor Module																																																											
A	2016	CTS	Body	Rear Short Range Radar Sensor Module																																																											
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																											
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																											
D	2004	(DM)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																											
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																											
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																											
D	2004	(DM)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																											
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2004	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2004	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2004	(DM)CTS	Chassis	VES																																																											
D	2004	(DM)CTS	Body	Amplifier (Bose)																																																											
D	2004	(DM)CTS	Body	Amplifier (Delco)																																																											
D	2004	(DM)CTS	Body	Climate Control Panel																																																											
D	2004	(DM)CTS	Body	Dash Integration Module																																																											
D	2004	(DM)CTS	Body	Digital Radio Receiver																																																											
D	2004	(DM)CTS	Body	Driver Door Switch																																																											
D	2004	(DM)CTS	Body	Driver Door Module																																																											
D	2004	(DM)CTS	Body	Passenger Door Module																																																											
D	2004	(DM)CTS	Body	Left Rear Door Module																																																											
D	2004	(DM)CTS	Body	Right Rear Door Module																																																											
D	2004	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2004	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2004	(DM)CTS	Body	Instrument Panel Cluster																																																										
D	2004	(DM)CTS	Body	Memory Seat Module																																																											
D	2004	(DM)CTS	Body	Personalization																																																											
D	2004	(DM)CTS	Body	Rear Integration Module																																																											
D	2004	(DM)CTS	Body	Remote Function Actuation																																																											
D	2004	(DM)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2004	(DM)CTS	Body	TV Antenna Module																																																											
D	2004	(DM)CTS	Body	Vehicle Theft Deterrent																																																											
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Auto																																																											
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Engine Control Module Manual																																																											
D	2004	(DR)CTS	Powertrain	(M)2.6L V6 LY9 Transmission Control Module																																																											
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Auto																																																											
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Engine Control Module Manual																																																											
D	2004	(DR)CTS	Powertrain	(N)3.2L V6 LA3 Transmission Control Module																																																											
D	2004	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2004	(DR)CTS	Chassis	VES																																																											
D	2004	(DR)CTS	Body	Amplifier (Bose)																																																											
D	2004	(DR)CTS	Body	Amplifier (Delco)																																																											
D	2004	(DR)CTS	Body	Climate Control Panel																																																											
D	2004	(DR)CTS	Body	Dash Integration Module																																																											
D	2004	(DR)CTS	Body	Digital Radio Receiver																																																											
D	2004	(DR)CTS	Body	Driver Door Switch																																																											
D	2004	(DR)CTS	Body	Driver Door Module																																																											
D	2004	(DR)CTS	Body	Passenger Door Module																																																											
D	2004	(DR)CTS	Body	Left Rear Door Module																																																											
D	2004	(DR)CTS	Body	Right Rear Door Module																																																											
D	2004	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2004	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2004	(DR)CTS	Body	Instrument Panel Cluster																																																											
D	2004	(DR)CTS	Body	Memory Seat Module																																																											
D	2004	(DR)CTS	Body	Personalization																																																											
D	2004	(DR)CTS	Body	Rear Integration Module																																																											
D	2004	(DR)CTS	Body	Remote Function Actuation																																																											
D	2004	(DR)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2004	(DR)CTS	Body	TV Antenna Module																																																											
D	2004	(DR)CTS	Body	Vehicle Theft Deterrent																																																											
D	2004	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																											
D	2004	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																											
D	2004	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																											
D	2004	(DN)CTS-V	Chassis	VES																																																											
D	2004	(DN)CTS-V	Body	Amplifier (Bose)																																																											
D	2004	(DN)CTS-V	Body	Amplifier (Delco)																																																											
D	2004	(DN)CTS-V	Body	Climate Control Panel																																																											
D	2004	(DN)CTS-V	Body	Dash Integration Module																																																											
D	2004	(DN)CTS-V	Body	Digital Radio Receiver																																																											
D	2004	(DN)CTS-V	Body	Driver Door Switch																																																											
D	2004	(DN)CTS-V	Body	Driver Door Module																																																											
D	2004	(DN)CTS-V	Body	Passenger Door Module																																																											
D	2004	(DN)CTS-V	Body	Left Rear Door Module																																																											
D	2004	(DN)CTS-V	Body	Right Rear Door Module																																																											
D	2004	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2004	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																										
D	2004	(DN)CTS-V	Body	Instrument Panel Cluster																																																											
D	2004	(DN)CTS-V	Body	Memory Seat Module																																																											
D	2004	(DN)CTS-V	Body	Personalization																																																											
D	2004	(DN)CTS-V	Body	Rear Integration Module																																																											
D	2004	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																											
D	2004	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																											
D	2004	(DN)CTS-V	Body	TV Antenna Module																																																											
D	2004	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																											
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2005	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2005	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2005	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2005	(DM)CTS	Chassis	VES																																																											
D	2005	(DM)CTS	Body	Amplifier (Bose)																																																											
D	2005	(DM)CTS	Body	Amplifier (Delco)																																																											
D	2005	(DM)CTS	Body	Climate Control Panel																																																											
D	2005	(DM)CTS	Body	Dash Integration Module																																																											
D	2005	(DM)CTS	Body	Digital Radio Receiver																																																											
D	2005	(DM)CTS	Body	Driver Door Switch																																																											
D	2005	(DM)CTS	Body	Driver Door Module																																																											
D	2005	(DM)CTS	Body	Passenger Door Module																																																											
D	2005	(DM)CTS	Body	Left Rear Door Module																																																											
D	2005	(DM)CTS	Body	Right Rear Door Module																																																											
D	2005	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2005	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2005	(DM)CTS	Body	Instrument Panel Cluster																																																											
D	2005	(DM)CTS	Body	Memory Seat Module																																																											
D	2005	(DM)CTS	Body	Personalization																																																											
D	2005	(DM)CTS	Body	Rear Integration Module																																																											
D	2005	(DM)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DM)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2005	(DM)CTS	Body	TV Antenna Module																																																											
D	2005	(DM)CTS	Body	Vehicle Theft Deterrent																																																											
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2005	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2005	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2005	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2005	(DP)CTS	Chassis	VES																																																											
D	2005	(DP)CTS	Body	Amplifier (Bose)																																																											
D	2005	(DP)CTS	Body	Amplifier (Delco)																																																											
D	2005	(DP)CTS	Body	Climate Control Panel																																																											
D	2005	(DP)CTS	Body	Dash Integration Module																																																											
D	2005	(DP)CTS	Body	Digital Radio Receiver																																																											
D	2005	(DP)CTS	Body	Driver Door Switch																																																											
D	2005	(DP)CTS	Body	Driver Door Module																																																											
D	2005	(DP)CTS	Body	Passenger Door Module																																																											
D	2005	(DP)CTS	Body	Left Rear Door Module																																																											
D	2005	(DP)CTS	Body	Right Rear Door Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2005	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2005	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2005	(DP)CTS	Body	Instrument Panel Cluster																																																										
D	2005	(DP)CTS	Body	Memory Seat Module																																																										
D	2005	(DP)CTS	Body	Personalization																																																										
D	2005	(DP)CTS	Body	Rear Integration Module																																																										
D	2005	(DP)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DP)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DP)CTS	Body	TV Antenna Module																																																										
D	2005	(DP)CTS	Body	Vehicle Theft Deterrent																																																										
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2005	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2005	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2005	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2005	(DR)CTS	Chassis	VES																																																										
D	2005	(DR)CTS	Body	Amplifier (Bose)																																																										
D	2005	(DR)CTS	Body	Amplifier (Delco)																																																										
D	2005	(DR)CTS	Body	Climate Control Panel																																																										
D	2005	(DR)CTS	Body	Dash Integration Module																																																										
D	2005	(DR)CTS	Body	Digital Radio Receiver																																																										
D	2005	(DR)CTS	Body	Driver Door Switch																																																										
D	2005	(DR)CTS	Body	Driver Door Module																																																										
D	2005	(DR)CTS	Body	Passenger Door Module																																																										
D	2005	(DR)CTS	Body	Left Rear Door Module																																																										
D	2005	(DR)CTS	Body	Right Rear Door Module																																																										
D	2005	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2005	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2005	(DR)CTS	Body	Instrument Panel Cluster																																																										
D	2005	(DR)CTS	Body	Memory Seat Module																																																										
D	2005	(DR)CTS	Body	Personalization																																																										
D	2005	(DR)CTS	Body	Radio																																																										
D	2005	(DR)CTS	Body	Rear Integration Module																																																										
D	2005	(DR)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DR)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DR)CTS	Body	TV Antenna Module																																																										
D	2005	(DR)CTS	Body	Vehicle Theft Deterrent																																																										
D	2005	(DN)CTS-V	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																										
D	2005	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																										
D	2005	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																										
D	2005	(DN)CTS-V	Chassis	VES																																																										
D	2005	(DN)CTS-V	Body	Amplifier (Bose)																																																										
D	2005	(DN)CTS-V	Body	Amplifier (Delco)																																																										
D	2005	(DN)CTS-V	Body	Climate Control Panel																																																										
D	2005	(DN)CTS-V	Body	Dash Integration Module																																																										
D	2005	(DN)CTS-V	Body	Digital Radio Receiver																																																										
D	2005	(DN)CTS-V	Body	Driver Door Switch																																																										
D	2005	(DN)CTS-V	Body	Driver Door Module																																																										
D	2005	(DN)CTS-V	Body	Passenger Door Module																																																										
D	2005	(DN)CTS-V	Body	Left Rear Door Module																																																										
D	2005	(DN)CTS-V	Body	Right Rear Door Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2005	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																										
D	2005	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																										
D	2005	(DN)CTS-V	Body	Instrument Panel Cluster																																																										
D	2005	(DN)CTS-V	Body	Memory Seat Module																																																										
D	2005	(DN)CTS-V	Body	Personalization																																																										
D	2005	(DN)CTS-V	Body	Radio																																																										
D	2005	(DN)CTS-V	Body	Rear Integration Module																																																										
D	2005	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DN)CTS-V	Body	TV Antenna Module																																																										
D	2005	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																										
D	2005	(DC)STS-V8	Powertrain	Engine Control Module																																																										
D	2005	(DC)STS-V8	Powertrain	Transmission Control Module																																																										
D	2005	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																										
D	2005	(DC)STS-V8	Chassis	Electronic Suspension Control																																																										
D	2005	(DC)STS-V8	Body	Amplifier (Bose)																																																										
D	2005	(DC)STS-V8	Body	Digital Radio Receiver																																																										
D	2005	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																										
D	2005	(DC)STS-V8	Body	Driver Door Module																																																										
D	2005	(DC)STS-V8	Body	Driver Door Switch																																																										
D	2005	(DC)STS-V8	Body	Driver Position Module																																																										
D	2005	(DC)STS-V8	Body	Headlamp Control Module																																																										
D	2005	(DC)STS-V8	Body	Head Up Display																																																										
D	2005	(DC)STS-V8	Body	HVAC Control Module																																																										
D	2005	(DC)STS-V8	Body	Instrument Panel Cluster																																																										
D	2005	(DC)STS-V8	Body	Instrument Panel Module																																																										
D	2005	(DC)STS-V8	Body	Left Rear Door Module																																																										
D	2005	(DC)STS-V8	Body	Passenger Door Module																																																										
D	2005	(DC)STS-V8	Body	Uplevel Radio																																																										
D	2005	(DC)STS-V8	Body	Navigation Radio																																																										
D	2005	(DC)STS-V8	Body	Rear Integration Module																																																										
D	2005	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																										
D	2005	(DC)STS-V8	Body	Right Rear Door Module																																																										
D	2005	(DC)STS-V8	Body	Steering Column Lock Module																																																										
D	2005	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																										
D	2005	(DC)STS-V8	Body	TV Antenna Module																																																										
D	2005	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																										
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2005	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2005	(DW)STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2005	(DW)STS	Chassis	Electronic Brake Control Module																																																										
D	2005	(DW)STS	Chassis	Electronic Suspension Control																																																										
D	2005	(DW)STS	Body	Amplifier (Bose)																																																										
D	2005	(DW)STS	Body	Digital Radio Receiver																																																										
D	2005	(DW)STS	Body	Distance Sensing Cruise Control																																																										
D	2005	(DW)STS	Body	Driver Door Module																																																										
D	2005	(DW)STS	Body	Driver Door Switch																																																										
D	2005	(DW)STS	Body	Driver Position Module																																																										
D	2005	(DW)STS	Body	Headlamp Control Module																																																										
D	2005	(DW)STS	Body	Head Up Display																																																										
D	2005	(DW)STS	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2005	(DW)STS	Body	Instrument Panel Cluster																																																										
D	2005	(DW)STS	Body	Instrument Panel Module																																																											
D	2005	(DW)STS	Body	Left Rear Door Module																																																											
D	2005	(DW)STS	Body	Passenger Door Module																																																											
D	2005	(DW)STS	Body	Uplevel Radio																																																											
D	2005	(DW)STS	Body	Navigation Radio																																																											
D	2005	(DW)STS	Body	Rear Integration Module																																																											
D	2005	(DW)STS	Body	Remote Control Door Lock Receiver																																																											
D	2005	(DW)STS	Body	Right Rear Door Module																																																											
D	2005	(DW)STS	Body	Steering Column Lock Module																																																											
D	2005	(DW)STS	Body	Supplemental Inflatable Restraint																																																											
D	2005	(DW)STS	Body	TV Antenna Module																																																											
D	2005	(DW)STS	Body	Vehicle Comm. Interface Module																																																											
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2006	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DM)CTS	Chassis	Tire Pressure Monitor																																																											
D	2006	(DM)CTS	Chassis	VES																																																											
D	2006	(DM)CTS	Body	Amplifier (Bose)																																																											
D	2006	(DM)CTS	Body	Amplifier (Delco)																																																											
D	2006	(DM)CTS	Body	Climate Control Panel																																																											
D	2006	(DM)CTS	Body	Dash Integration Module																																																											
D	2006	(DM)CTS	Body	Digital Radio Receiver																																																											
D	2006	(DM)CTS	Body	Driver Door Switch																																																											
D	2006	(DM)CTS	Body	Driver Door Module																																																											
D	2006	(DM)CTS	Body	Passenger Door Module																																																											
D	2006	(DM)CTS	Body	Left Rear Door Module																																																											
D	2006	(DM)CTS	Body	Right Rear Door Module																																																											
D	2006	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DM)CTS	Body	Instrument Panel Cluster																																																											
D	2006	(DM)CTS	Body	Memory Seat Module																																																											
D	2006	(DM)CTS	Body	Personalization																																																											
D	2006	(DM)CTS	Body	Radio																																																											
D	2006	(DM)CTS	Body	Rear Integration Module																																																											
D	2006	(DM)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DM)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DM)CTS	Body	TV Antenna Module																																																											
D	2006	(DM)CTS	Body	Vehicle Theft Deterrent																																																											
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2006	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DP)CTS	Chassis	Tire Pressure Monitor																																																											
D	2006	(DP)CTS	Chassis	VES																																																											
D	2006	(DP)CTS	Body	Amplifier (Bose)																																																											
D	2006	(DP)CTS	Body	Amplifier (Delco)																																																											
D	2006	(DP)CTS	Body	Climate Control Panel																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2006	(DP)CTS	Body	Dash Integration Module																																																										
D	2006	(DP)CTS	Body	Digital Radio Receiver																																																											
D	2006	(DP)CTS	Body	Driver Door Switch																																																											
D	2006	(DP)CTS	Body	Driver Door Module																																																											
D	2006	(DP)CTS	Body	Passenger Door Module																																																											
D	2006	(DP)CTS	Body	Left Rear Door Module																																																											
D	2006	(DP)CTS	Body	Right Rear Door Module																																																											
D	2006	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DP)CTS	Body	Instrument Panel Cluster																																																											
D	2006	(DP)CTS	Body	Memory Seat Module																																																											
D	2006	(DP)CTS	Body	Personalization																																																											
D	2006	(DP)CTS	Body	Radio																																																											
D	2006	(DP)CTS	Body	Rear Integration Module																																																											
D	2006	(DP)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DP)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DP)CTS	Body	TV Antenna Module																																																											
D	2006	(DP)CTS	Body	Vehicle Theft Deterrent																																																											
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2006	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DR)CTS	Chassis	Tire Pressure Monitor																																																											
D	2006	(DR)CTS	Chassis	VES																																																											
D	2006	(DR)CTS	Body	Amplifier (Bose)																																																											
D	2006	(DR)CTS	Body	Amplifier (Delco)																																																											
D	2006	(DR)CTS	Body	Climate Control Panel																																																											
D	2006	(DR)CTS	Body	Dash Integration Module																																																											
D	2006	(DR)CTS	Body	Digital Radio Receiver																																																											
D	2006	(DR)CTS	Body	Driver Door Switch																																																											
D	2006	(DR)CTS	Body	Driver Door Module																																																											
D	2006	(DR)CTS	Body	Passenger Door Module																																																											
D	2006	(DR)CTS	Body	Left Rear Door Module																																																											
D	2006	(DR)CTS	Body	Right Rear Door Module																																																											
D	2006	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DR)CTS	Body	Instrument Panel Cluster																																																											
D	2006	(DR)CTS	Body	Memory Seat Module																																																											
D	2006	(DR)CTS	Body	Personalization																																																											
D	2006	(DR)CTS	Body	Radio																																																											
D	2006	(DR)CTS	Body	Rear Integration Module																																																											
D	2006	(DR)CTS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DR)CTS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DR)CTS	Body	TV Antenna Module																																																											
D	2006	(DR)CTS	Body	Vehicle Theft Deterrent																																																											
D	2006	(DN)CTS-V	Powertrain	Engine Control Module																																																											
D	2006	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																											
D	2006	(DN)CTS-V	Chassis	Tire Pressure Monitor																																																											
D	2006	(DN)CTS-V	Chassis	VES																																																											
D	2006	(DN)CTS-V	Body	Amplifier (Bose)																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2006	(DN)CTS-V	Body	Amplifier (Delco)																																																										
D	2006	(DN)CTS-V	Body	Climate Control Panel																																																											
D	2006	(DN)CTS-V	Body	Dash Integration Module																																																											
D	2006	(DN)CTS-V	Body	Digital Radio Receiver																																																											
D	2006	(DN)CTS-V	Body	Driver Door Switch																																																											
D	2006	(DN)CTS-V	Body	Driver Door Module																																																											
D	2006	(DN)CTS-V	Body	Passenger Door Module																																																											
D	2006	(DN)CTS-V	Body	Left Rear Door Module																																																											
D	2006	(DN)CTS-V	Body	Right Rear Door Module																																																											
D	2006	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																											
D	2006	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																											
D	2006	(DN)CTS-V	Body	Instrument Panel Cluster																																																											
D	2006	(DN)CTS-V	Body	Memory Seat Module																																																											
D	2006	(DN)CTS-V	Body	Personalization																																																											
D	2006	(DN)CTS-V	Body	Rear Integration Module																																																											
D	2006	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DN)CTS-V	Body	TV Antenna Module																																																											
D	2006	(DN)CTS-V	Body	Vehicle Theft Deterrent																																																											
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Engine Controls																																																											
D	2006	(DC)STS-V8	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
D	2006	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																											
D	2006	(DC)STS-V8	Chassis	Electronic Suspension Control																																																											
D	2006	(DC)STS-V8	Body	Amplifier (Bose)																																																											
D	2006	(DC)STS-V8	Body	Digital Radio Receiver																																																											
D	2006	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																											
D	2006	(DC)STS-V8	Body	Driver Door Module																																																											
D	2006	(DC)STS-V8	Body	Driver Door Switch																																																											
D	2006	(DC)STS-V8	Body	Driver Position Module																																																											
D	2006	(DC)STS-V8	Body	Headlamp Control Module																																																											
D	2006	(DC)STS-V8	Body	Head Up Display																																																											
D	2006	(DC)STS-V8	Body	HVAC Control Module																																																											
D	2006	(DC)STS-V8	Body	Instrument Panel Cluster																																																											
D	2006	(DC)STS-V8	Body	Instrument Panel Module																																																											
D	2006	(DC)STS-V8	Body	Left Rear Door Module																																																											
D	2006	(DC)STS-V8	Body	Passenger Door Module																																																											
D	2006	(DC)STS-V8	Body	Uplevel Radio																																																											
D	2006	(DC)STS-V8	Body	Navigation Radio																																																											
D	2006	(DC)STS-V8	Body	Rear Integration Module																																																											
D	2006	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DC)STS-V8	Body	Right Rear Door Module																																																											
D	2006	(DC)STS-V8	Body	Steering Column Lock Module																																																											
D	2006	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DC)STS-V8	Body	TV Antenna Module																																																											
D	2006	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																											
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2006	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2006	(DW)STS	Chassis	Electronic Brake Control Module																																																											
D	2006	(DW)STS	Chassis	Electronic Suspension Control																																																											
D	2006	(DW)STS	Body	Amplifier (Bose)																																																											
D	2006	(DW)STS	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2006	(DW)STS	Body	Distance Sensing Cruise Control																																																										
D	2006	(DW)STS	Body	Driver Door Module																																																											
D	2006	(DW)STS	Body	Driver Door Switch																																																											
D	2006	(DW)STS	Body	Driver Position Module																																																											
D	2006	(DW)STS	Body	Headlamp Control Module																																																											
D	2006	(DW)STS	Body	Head Up Display																																																											
D	2006	(DW)STS	Body	HVAC Control Module																																																											
D	2006	(DW)STS	Body	Instrument Panel Cluster																																																											
D	2006	(DW)STS	Body	Instrument Panel Module																																																											
D	2006	(DW)STS	Body	Left Rear Door Module																																																											
D	2006	(DW)STS	Body	Passenger Door Module																																																											
D	2006	(DW)STS	Body	Uplevel Radio																																																											
D	2006	(DW)STS	Body	Navigation Radio																																																											
D	2006	(DW)STS	Body	Rear Integration Module																																																											
D	2006	(DW)STS	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DW)STS	Body	Right Rear Door Module																																																											
D	2006	(DW)STS	Body	Steering Column Lock Module																																																											
D	2006	(DW)STS	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DW)STS	Body	TV Antenna Module																																																											
D	2006	(DW)STS	Body	Vehicle Comm. Interface Module																																																											
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																											
D	2006	(DX)STS-V	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																											
D	2006	(DX)STS-V	Chassis	Electronic Brake Control Module																																																											
D	2006	(DX)STS-V	Chassis	Electronic Suspension Control																																																											
D	2006	(DX)STS-V	Body	Amplifier (Bose)																																																											
D	2006	(DX)STS-V	Body	Digital Radio Receiver																																																											
D	2006	(DX)STS-V	Body	Distance Sensing Cruise Control																																																											
D	2006	(DX)STS-V	Body	Driver Door Module																																																											
D	2006	(DX)STS-V	Body	Driver Door Switch																																																											
D	2006	(DX)STS-V	Body	Driver Position Module																																																											
D	2006	(DX)STS-V	Body	Headlamp Control Module																																																											
D	2006	(DX)STS-V	Body	Head Up Display																																																											
D	2006	(DX)STS-V	Body	HVAC Control Module																																																											
D	2006	(DX)STS-V	Body	Instrument Panel Cluster																																																											
D	2006	(DX)STS-V	Body	Instrument Panel Module																																																											
D	2006	(DX)STS-V	Body	Left Rear Door Module																																																											
D	2006	(DX)STS-V	Body	Passenger Door Module																																																											
D	2006	(DX)STS-V	Body	Uplevel Radio																																																											
D	2006	(DX)STS-V	Body	Navigation Radio																																																											
D	2006	(DX)STS-V	Body	Rear Integration Module																																																											
D	2006	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																											
D	2006	(DX)STS-V	Body	Right Rear Door Module																																																											
D	2006	(DX)STS-V	Body	Steering Column Lock Module																																																											
D	2006	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																											
D	2006	(DX)STS-V	Body	TV Antenna Module																																																											
D	2006	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																											
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																											
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																											
D	2007	(DM)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																											
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2007	(DM)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2007	(DM)CTS	Chassis	DRP/ABS/TCS/VSES																																																									
D	2007	(DM)CTS	Chassis	VES																																																									
D	2007	(DM)CTS	Body	Amplifier (Bose)																																																										
D	2007	(DM)CTS	Body	Amplifier (Delco)																																																										
D	2007	(DM)CTS	Body	Climate Control Panel																																																										
D	2007	(DM)CTS	Body	Dash Integration Module																																																										
D	2007	(DM)CTS	Body	Digital Radio Receiver																																																										
D	2007	(DM)CTS	Body	Driver Door Switch																																																										
D	2007	(DM)CTS	Body	Driver Door Module																																																										
D	2007	(DM)CTS	Body	Passenger Door Module																																																										
D	2007	(DM)CTS	Body	Left Rear Door Module																																																										
D	2007	(DM)CTS	Body	Right Rear Door Module																																																										
D	2007	(DM)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2007	(DM)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2007	(DM)CTS	Body	Instrument Panel Cluster																																																										
D	2007	(DM)CTS	Body	Memory Seat Module																																																										
D	2007	(DM)CTS	Body	Personalization																																																										
D	2007	(DM)CTS	Body	Rear Integration Module																																																										
D	2007	(DM)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2007	(DM)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DM)CTS	Body	Theft Deterrent Module																																																										
D	2007	(DM)CTS	Body	TV Antenna Module																																																										
D	2007	(DM)CTS	Body	Vehicle Comm. Interface Module																																																										
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																										
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																										
D	2007	(DP)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																										
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																										
D	2007	(DP)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2007	(DP)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2007	(DP)CTS	Chassis	VES																																																										
D	2007	(DP)CTS	Body	Amplifier (Bose)																																																										
D	2007	(DP)CTS	Body	Amplifier (Delco)																																																										
D	2007	(DP)CTS	Body	Climate Control Panel																																																										
D	2007	(DP)CTS	Body	Dash Integration Module																																																										
D	2007	(DP)CTS	Body	Digital Radio Receiver																																																										
D	2007	(DP)CTS	Body	Driver Door Switch																																																										
D	2007	(DP)CTS	Body	Driver Door Module																																																										
D	2007	(DP)CTS	Body	Passenger Door Module																																																										
D	2007	(DP)CTS	Body	Left Rear Door Module																																																										
D	2007	(DP)CTS	Body	Right Rear Door Module																																																										
D	2007	(DP)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2007	(DP)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2007	(DP)CTS	Body	Instrument Panel Cluster																																																										
D	2007	(DP)CTS	Body	Memory Seat Module																																																										
D	2007	(DP)CTS	Body	Personalization																																																										
D	2007	(DP)CTS	Body	Rear Integration Module																																																										
D	2007	(DP)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2007	(DP)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DP)CTS	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2007	(DP)CTS	Body	TV Antenna Module																																																										
D	2007	(DP)CTS	Body	Vehicle Comm. Interface Module																																																										
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Auto																																																										
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module Manual																																																										
D	2007	(DR)CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Auto																																																										
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module Manual																																																										
D	2007	(DR)CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2007	(DR)CTS	Chassis	DRP/ABS/TCS/VSES																																																										
D	2007	(DR)CTS	Chassis	VES																																																										
D	2007	(DR)CTS	Body	Amplifier (Bose)																																																										
D	2007	(DR)CTS	Body	Amplifier (Delco)																																																										
D	2007	(DR)CTS	Body	Climate Control Panel																																																										
D	2007	(DR)CTS	Body	Dash Integration Module																																																										
D	2007	(DR)CTS	Body	Digital Radio Receiver																																																										
D	2007	(DR)CTS	Body	Driver Door Switch																																																										
D	2007	(DR)CTS	Body	Driver Door Module																																																										
D	2007	(DR)CTS	Body	Passenger Door Module																																																										
D	2007	(DR)CTS	Body	Left Rear Door Module																																																										
D	2007	(DR)CTS	Body	Right Rear Door Module																																																										
D	2007	(DR)CTS	Body	Lt. Headlamp Leveling Mod.																																																										
D	2007	(DR)CTS	Body	Rt. Headlamp Leveling Mod.																																																										
D	2007	(DR)CTS	Body	Instrument Panel Cluster																																																										
D	2007	(DR)CTS	Body	Memory Seat Module																																																										
D	2007	(DR)CTS	Body	Personalization																																																										
D	2007	(DR)CTS	Body	Rear Integration Module																																																										
D	2007	(DR)CTS	Body	Remote Control Door Lock Receiver																																																										
D	2007	(DR)CTS	Body	Supplemental Inflatable Restraint																																																										
D	2007	(DR)CTS	Body	Theft Deterrent Module																																																										
D	2007	(DR)CTS	Body	TV Antenna Module																																																										
D	2007	(DR)CTS	Body	Vehicle Comm. Interface Module																																																										
D	2007	(DN)CTS-V	Powertrain	(U)6.0L V8 LS2 Engine Control Module																																																										
D	2007	(DN)CTS-V	Chassis	DRP/ABS/TCS/VSES																																																										
D	2007	(DN)CTS-V	Chassis	VES																																																										
D	2007	(DN)CTS-V	Body	Amplifier (Bose)																																																										
D	2007	(DN)CTS-V	Body	Amplifier (Delco)																																																										
D	2007	(DN)CTS-V	Body	Climate Control Panel																																																										
D	2007	(DN)CTS-V	Body	Dash Integration Module																																																										
D	2007	(DN)CTS-V	Body	Digital Radio Receiver																																																										
D	2007	(DN)CTS-V	Body	Driver Door Switch																																																										
D	2007	(DN)CTS-V	Body	Driver Door Module																																																										
D	2007	(DN)CTS-V	Body	Passenger Door Module																																																										
D	2007	(DN)CTS-V	Body	Left Rear Door Module																																																										
D	2007	(DN)CTS-V	Body	Right Rear Door Module																																																										
D	2007	(DN)CTS-V	Body	Lt. Headlamp Leveling Mod.																																																										
D	2007	(DN)CTS-V	Body	Rt. Headlamp Leveling Mod.																																																										
D	2007	(DN)CTS-V	Body	Instrument Panel Cluster																																																										
D	2007	(DN)CTS-V	Body	Memory Seat Module																																																										
D	2007	(DN)CTS-V	Body	Personalization																																																										
D	2007	(DN)CTS-V	Body	Rear Integration Module																																																										
D	2007	(DN)CTS-V	Body	Remote Control Door Lock Receiver																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2007	(DN)CTS-V	Body	Supplemental Inflatable Restraint																																																								
D	2007	(DN)CTS-V	Body	Theft Deterrent Module																																																								
D	2007	(DN)CTS-V	Body	TV Antenna Module																																																								
D	2007	(DN)CTS-V	Body	Vehicle Comm. Interface Module																																																								
D	2007	(DC)STS-V8	Powertrain	Engine Control Module																																																								
D	2007	(DC)STS-V8	Powertrain	Transmission Control Module																																																								
D	2007	(DC)STS-V8	Chassis	Electronic Brake Control Module																																																								
D	2007	(DC)STS-V8	Chassis	Electronic Suspension Control																																																								
D	2007	(DC)STS-V8	Body	Amplifier (Bose)																																																								
D	2007	(DC)STS-V8	Body	Digital Radio Receiver																																																								
D	2007	(DC)STS-V8	Body	Distance Sensing Cruise Control																																																								
D	2007	(DC)STS-V8	Body	Driver Door Module																																																								
D	2007	(DC)STS-V8	Body	Driver Door Switch																																																								
D	2007	(DC)STS-V8	Body	Driver Position Module																																																								
D	2007	(DC)STS-V8	Body	Headlamp Control Module																																																								
D	2007	(DC)STS-V8	Body	Head Up Display																																																								
D	2007	(DC)STS-V8	Body	HVAC Control Module																																																								
D	2007	(DC)STS-V8	Body	Instrument Panel Cluster																																																								
D	2007	(DC)STS-V8	Body	Instrument Panel Module																																																								
D	2007	(DC)STS-V8	Body	Left Rear Door Module																																																								
D	2007	(DC)STS-V8	Body	Passenger Door Module																																																								
D	2007	(DC)STS-V8	Body	Uplevel Radio																																																								
D	2007	(DC)STS-V8	Body	Navigation Radio																																																								
D	2007	(DC)STS-V8	Body	Rear Integration Module																																																								
D	2007	(DC)STS-V8	Body	Remote Control Door Lock Receiver																																																								
D	2007	(DC)STS-V8	Body	Right Rear Door Module																																																								
D	2007	(DC)STS-V8	Body	Steering Column Lock Module																																																								
D	2007	(DC)STS-V8	Body	Supplemental Inflatable Restraint																																																								
D	2007	(DC)STS-V8	Body	TV Antenna Module																																																								
D	2007	(DC)STS-V8	Body	Vehicle Comm. Interface Module																																																								
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
D	2007	(DW)STS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
D	2007	(DW)STS	Chassis	Electronic Brake Control Module																																																								
D	2007	(DW)STS	Chassis	Electronic Suspension Control																																																								
D	2007	(DW)STS	Body	Amplifier (Bose)																																																								
D	2007	(DW)STS	Body	Digital Radio Receiver																																																								
D	2007	(DW)STS	Body	Distance Sensing Cruise Control																																																								
D	2007	(DW)STS	Body	Driver Door Module																																																								
D	2007	(DW)STS	Body	Driver Door Switch																																																								
D	2007	(DW)STS	Body	Driver Position Module																																																								
D	2007	(DW)STS	Body	Headlamp Control Module																																																								
D	2007	(DW)STS	Body	Head Up Display																																																								
D	2007	(DW)STS	Body	HVAC Control Module																																																								
D	2007	(DW)STS	Body	Instrument Panel Cluster																																																								
D	2007	(DW)STS	Body	Instrument Panel Module																																																								
D	2007	(DW)STS	Body	Left Rear Door Module																																																								
D	2007	(DW)STS	Body	Passenger Door Module																																																								
D	2007	(DW)STS	Body	Uplevel Radio																																																								
D	2007	(DW)STS	Body	Navigation Radio																																																								
D	2007	(DW)STS	Body	Rear Integration Module																																																								
D	2007	(DW)STS	Body	Remote Control Door Lock Receiver																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2007	(DW)STS	Body	Right Rear Door Module																																																										
D	2007	(DW)STS	Body	Steering Column Lock Module																																																											
D	2007	(DW)STS	Body	Supplemental Inflatable Restraint																																																											
D	2007	(DW)STS	Body	TV Antenna Module																																																											
D	2007	(DW)STS	Body	Vehicle Comm. Interface Module																																																											
D	2007	(DX)STS-V	Powertrain	Engine Control Module																																																											
D	2007	(DX)STS-V	Powertrain	Transmission Control Module																																																											
D	2007	(DX)STS-V	Chassis	Electronic Brake Control Module																																																											
D	2007	(DX)STS-V	Chassis	Electronic Suspension Control																																																											
D	2007	(DX)STS-V	Body	Amplifier (Bose)																																																											
D	2007	(DX)STS-V	Body	Digital Radio Receiver																																																											
D	2007	(DX)STS-V	Body	Distance Sensing Cruise Control																																																											
D	2007	(DX)STS-V	Body	Driver Door Module																																																											
D	2007	(DX)STS-V	Body	Driver Door Switch																																																											
D	2007	(DX)STS-V	Body	Driver Position Module																																																											
D	2007	(DX)STS-V	Body	Headlamp Control Module																																																											
D	2007	(DX)STS-V	Body	Head Up Display																																																											
D	2007	(DX)STS-V	Body	HVAC Control Module																																																											
D	2007	(DX)STS-V	Body	Instrument Panel Cluster																																																											
D	2007	(DX)STS-V	Body	Instrument Panel Module																																																											
D	2007	(DX)STS-V	Body	Left Rear Door Module																																																											
D	2007	(DX)STS-V	Body	Passenger Door Module																																																											
D	2007	(DX)STS-V	Body	Uplevel Radio																																																											
D	2007	(DX)STS-V	Body	Navigation Radio																																																											
D	2007	(DX)STS-V	Body	Rear Integration Module																																																											
D	2007	(DX)STS-V	Body	Remote Control Door Lock Receiver																																																											
D	2007	(DX)STS-V	Body	Right Rear Door Module																																																											
D	2007	(DX)STS-V	Body	Steering Column Lock Module																																																											
D	2007	(DX)STS-V	Body	Supplemental Inflatable Restraint																																																											
D	2007	(DX)STS-V	Body	TV Antenna Module																																																											
D	2007	(DX)STS-V	Body	Vehicle Comm. Interface Module																																																											
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2008	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																											
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																											
D	2008	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																											
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2008	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																											
D	2008	CTS	Chassis	Electronic Brake Control Module																																																											
D	2008	CTS	Body	Body Control Module																																																											
D	2008	CTS	Body	Body Control Module (aux.)																																																											
D	2008	CTS	Body	Driver Door Switch																																																											
D	2008	CTS	Body	Headlamp Control Module																																																											
D	2008	CTS	Body	HVAC Control Module																																																											
D	2008	CTS	Body	Infotainment Faceplate Module																																																											
D	2008	CTS	Body	Instrument Panel Cluster																																																											
D	2008	CTS	Body	Memory Seat Module																																																											
D	2008	CTS	Body	Park Assist Module																																																											
D	2008	CTS	Body	Passenger Door Switch																																																											
D	2008	CTS	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2008	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2008	CTS	Body	Radio																																																										
D	2008	CTS	Body	Supplemental Inflatable Restraint																																																										
D	2008	CTS	Body	TV Antenna Module																																																										
D	2008	CTS	Body	Vehicle Comm. Interface Module																																																										
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																										
D	2008	SLS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																										
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
D	2008	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
D	2008	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2008	SLS	Chassis	Electronic Brake Control Module																																																										
D	2008	SLS	Chassis	Electronic Suspension Control																																																										
D	2008	SLS	Body	Amplifier (Bose)																																																										
D	2008	SLS	Body	Driver Door Module																																																										
D	2008	SLS	Body	Driver Door Switch																																																										
D	2008	SLS	Body	Driver Position Module																																																										
D	2008	SLS	Body	Headlamp Control Module																																																										
D	2008	SLS	Body	HVAC Control Module																																																										
D	2008	SLS	Body	Instrument Panel Cluster																																																										
D	2008	SLS	Body	Instrument Panel Module																																																										
D	2008	SLS	Body	Left Rear Door Module																																																										
D	2008	SLS	Body	Passenger Door Module																																																										
D	2008	SLS	Body	Radio																																																										
D	2008	SLS	Body	Rear HVAC/RSA																																																										
D	2008	SLS	Body	Rear Integration Module																																																										
D	2008	SLS	Body	Remote Control Door Lock Receiver																																																										
D	2008	SLS	Body	Right Rear Door Module																																																										
D	2008	SLS	Body	Supplemental Inflatable Restraint																																																										
D	2008	SLS	Body	TV Antenna Module																																																										
D	2008	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																										
D	2008	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
D	2008	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
D	2008	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2008	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																										
D	2008	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																										
D	2008	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																										
D	2008	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																										
D	2008	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																										
D	2008	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																										
D	2008	STS	Body	Amplifier (Bose)																																																										
D	2008	STS	Body	Digital Radio Receiver																																																										
D	2008	STS	Body	Distance Sensing Cruise Control																																																										
D	2008	STS	Body	Driver Door Module																																																										
D	2008	STS	Body	Driver Door Switch																																																										
D	2008	STS	Body	Driver Position Module																																																										
D	2008	STS	Body	Headlamp Control Module																																																										
D	2008	STS	Body	Head Up Display																																																										
D	2008	STS	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2008	STS	Body	Instrument Panel Cluster																																																										
D	2008	STS	Body	Instrument Panel Module																																																											
D	2008	STS	Body	Left Rear Door Module																																																											
D	2008	STS	Body	Left Side Object Detection Module																																																											
D	2008	STS	Body	Passenger Door Module																																																											
D	2008	STS	Body	Uplevel Radio																																																											
D	2008	STS	Body	Navigation Radio																																																											
D	2008	STS	Body	Rear Integration Module																																																											
D	2008	STS	Body	Remote Control Door Lock Receiver																																																											
D	2008	STS	Body	Right Rear Door Module																																																											
D	2008	STS	Body	Right Side Object Detection Module																																																											
D	2008	STS	Body	Steering Column Lock Module																																																											
D	2008	STS	Body	Supplemental Inflatable Restraint																																																											
D	2008	STS	Body	TV Antenna Module																																																											
D	2008	STS	Body	Vehicle Comm. Interface Module																																																											
D	2008	STS	Body	Veh Direction Alert Alarm Warn Mod																																																											
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																											
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																											
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																											
D	2009	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																											
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2009	CTS	Powertrain	(T)2.8L V6 LP1 Transmission Control Module																																																											
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																											
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																											
D	2009	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																											
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
D	2009	CTS	Powertrain	(7)3.6L V6 LY7 Transfer Case Control Module																																																											
D	2009	CTS	Chassis	Electronic Brake Control Module																																																											
D	2009	CTS	Chassis	Electronic Suspension Control																																																											
D	2009	CTS	Chassis	Parking Brake Control Module																																																											
D	2009	CTS	Body	Body Control Module																																																											
D	2009	CTS	Body	Body Control Module (aux.)																																																											
D	2009	CTS	Body	Driver Door Switch																																																											
D	2009	CTS	Body	Headlamp Control Module																																																											
D	2009	CTS	Body	HVAC Control Module																																																											
D	2009	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																											
D	2009	CTS	Body	Instrument Panel Cluster (Other)																																																											
D	2009	CTS	Body	Memory Seat Module																																																											
D	2009	CTS	Body	Park Assist Module																																																											
D	2009	CTS	Body	Passenger Door Switch																																																											
D	2009	CTS	Body	Passenger Presence System																																																											
D	2009	CTS	Body	Pedestrian Impact Detection Module																																																											
D	2009	CTS	Body	Radio																																																											
D	2009	CTS	Body	Supplemental Inflatable Restraint																																																											
D	2009	CTS	Body	TV Antenna Module																																																											
D	2009	CTS	Body	Vehicle Comm. Interface Module																																																											
D	2009	SLS	Powertrain	(T)2.8L V6 LP1 Engine Control Module																																																											
D	2009	SLS	Powertrain	(T)2.8L V6 LP2 Transmission Control Module																																																											
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
D	2009	SLS	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																									
D	2009	SLS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																									
D	2009	SLS	Chassis	Electronic Brake Control Module																																																										
D	2009	SLS	Chassis	Electronic Suspension Control																																																										
D	2009	SLS	Body	Amplifier (Bose)																																																										
D	2009	SLS	Body	Driver Door Module																																																										
D	2009	SLS	Body	Driver Door Switch																																																										
D	2009	SLS	Body	Driver Position Module																																																										
D	2009	SLS	Body	Headlamp Control Module																																																										
D	2009	SLS	Body	HVAC Control Module																																																										
D	2009	SLS	Body	Instrument Panel Cluster																																																										
D	2009	SLS	Body	Instrument Panel Module																																																										
D	2009	SLS	Body	Left Rear Door Module																																																										
D	2009	SLS	Body	Passenger Door Module																																																										
D	2009	SLS	Body	Radio																																																										
D	2009	SLS	Body	Rear HVAC/RSA																																																										
D	2009	SLS	Body	Rear Integration Module																																																										
D	2009	SLS	Body	Remote Control Door Lock Receiver																																																										
D	2009	SLS	Body	Right Rear Door Module																																																										
D	2009	SLS	Body	Supplemental Inflatable Restraint																																																										
D	2009	SLS	Body	TV Antenna Module																																																										
D	2009	SLS	Body	Vehicle Comm. Interface Module																																																										
D	2009	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																										
D	2009	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
D	2009	STS	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
D	2009	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2009	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																										
D	2009	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																										
D	2009	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																										
D	2009	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																										
D	2009	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																										
D	2009	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																										
D	2009	STS	Body	Amplifier (Bose)																																																										
D	2009	STS	Body	Digital Radio Receiver																																																										
D	2009	STS	Body	Distance Sensing Cruise Control																																																										
D	2009	STS	Body	Driver Door Module																																																										
D	2009	STS	Body	Driver Door Switch																																																										
D	2009	STS	Body	Driver Position Module																																																										
D	2009	STS	Body	Headlamp Control Module																																																										
D	2009	STS	Body	Head Up Display																																																										
D	2009	STS	Body	HVAC Control Module																																																										
D	2009	STS	Body	Instrument Panel Cluster																																																										
D	2009	STS	Body	Instrument Panel Module																																																										
D	2009	STS	Body	Left Rear Door Module																																																										
D	2009	STS	Body	Left Side Object Detection Module																																																										
D	2009	STS	Body	Passenger Door Module																																																										
D	2009	STS	Body	Uplevel Radio																																																										
D	2009	STS	Body	Navigation Radio																																																										
D	2009	STS	Body	Rear Integration Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2009	STS	Body	Remote Control Door Lock Receiver																																																										
D	2009	STS	Body	Right Rear Door Module																																																										
D	2009	STS	Body	Right Side Object Detection Module																																																										
D	2009	STS	Body	Steering Column Lock Module																																																										
D	2009	STS	Body	Supplemental Inflatable Restraint																																																										
D	2009	STS	Body	TV Antenna Module																																																										
D	2009	STS	Body	Vehicle Comm. Interface Module																																																										
D	2009	STS	Body	Veh Direction Alert Alarm Warn Mod																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Auto																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Engine Control Module Manual																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transmission Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(G)3.0L V6 LF1 Transfer Case Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Engine Control Module Auto																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Fuel Pump Control Module																																																										
D	2010	CTS	Powertrain	(V)3.6L V6 LLT Transfer Case Control Module																																																										
D	2010	CTS	Chassis	Electronic Brake Control Module																																																										
D	2010	CTS	Chassis	Electronic Suspension Control																																																										
D	2010	CTS	Chassis	Parking Brake Control Module																																																										
D	2010	CTS	Body	Body Control Module																																																										
D	2010	CTS	Body	Body Control Module (aux.)																																																										
D	2010	CTS	Body	Driver Door Switch																																																										
D	2010	CTS	Body	Headlamp Control Module																																																										
D	2010	CTS	Body	HVAC Control Module																																																										
D	2010	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																										
D	2010	CTS	Body	Instrument Panel Cluster (Other)																																																										
D	2010	CTS	Body	Liftgate Module																																																										
D	2010	CTS	Body	Memory Seat Module																																																										
D	2010	CTS	Body	Park Assist Module																																																										
D	2010	CTS	Body	Passenger Door Switch																																																										
D	2010	CTS	Body	Passenger Presence System																																																										
D	2010	CTS	Body	Pedestrian Impact Detection Module																																																										
D	2010	CTS	Body	Radio																																																										
D	2010	CTS	Body	Supplemental Inflatable Restraint																																																										
D	2010	CTS	Body	TV Antenna Module																																																										
D	2010	CTS	Body	Vehicle Comm. Interface Module																																																										
D	2010	STS	Powertrain	(V)3.6L V6 LLT Engine Control Module																																																										
D	2010	STS	Powertrain	(V)3.6L V6 LLT Transmission Control Module																																																										
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
D	2010	STS	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
D	2010	STS	Chassis	Electronic Brake Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Suspension Control With (RPO JL7)																																																										
D	2010	STS	Chassis	Power Steering Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Vehicle Stability Control Module With (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Brake Control Module Without (RPO JL7)																																																										
D	2010	STS	Chassis	Electronic Suspension Control Without (RPO JL7)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2010	STS	Body	Amplifier (Bose)																																																										
D	2010	STS	Body	Digital Radio Receiver																																																										
D	2010	STS	Body	Distance Sensing Cruise Control																																																										
D	2010	STS	Body	Driver Door Module																																																										
D	2010	STS	Body	Driver Door Switch																																																										
D	2010	STS	Body	Driver Position Module																																																										
D	2010	STS	Body	Headlamp Control Module																																																										
D	2010	STS	Body	Head Up Display																																																										
D	2010	STS	Body	HVAC Control Module																																																										
D	2010	STS	Body	Instrument Panel Cluster																																																										
D	2010	STS	Body	Instrument Panel Module																																																										
D	2010	STS	Body	Left Rear Door Module																																																										
D	2010	STS	Body	Left Side Object Detection Module																																																										
D	2010	STS	Body	Passenger Door Module																																																										
D	2010	STS	Body	Uplevel Radio																																																										
D	2010	STS	Body	Navigation Radio																																																										
D	2010	STS	Body	Rear Integration Module																																																										
D	2010	STS	Body	Remote Control Door Lock Receiver																																																										
D	2010	STS	Body	Right Rear Door Module																																																										
D	2010	STS	Body	Right Side Object Detection Module																																																										
D	2010	STS	Body	Steering Column Lock Module																																																										
D	2010	STS	Body	Supplemental Inflatable Restraint																																																										
D	2010	STS	Body	TV Antenna Module																																																										
D	2010	STS	Body	Vehicle Comm. Interface Module																																																										
D	2010	STS	Body	Veh Direction Alert Alarm Warn Mod																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2011	CTS	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Auto																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Engine Control Module Manual																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																										
D	2011	CTS	Powertrain	(Y)3.0L V6 LF1 Transfer Case Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Fuel Pump Control Module																																																										
D	2011	CTS	Powertrain	(D)3.6L V6 LLT Transfer Case Control Module																																																										
D	2011	CTS	Chassis	Electronic Brake Control Module																																																										
D	2011	CTS	Chassis	Electronic Suspension Control																																																										
D	2011	CTS	Chassis	Parking Brake Control Module																																																										
D	2011	CTS	Body	Body Control Module (6.2L V8 LSA)																																																										
D	2011	CTS	Body	Body Control Module (Other)																																																										
D	2011	CTS	Body	Body Control Module (aux.)																																																										
D	2011	CTS	Body	Driver Door Switch																																																										
D	2011	CTS	Body	Headlamp Control Module																																																										
D	2011	CTS	Body	HVAC Control Module																																																										
D	2011	CTS	Body	Instrument Panel Cluster (6.2L V8 LSA)																																																										
D	2011	CTS	Body	Instrument Panel Cluster (Other)																																																										
D	2011	CTS	Body	Liftgate Module																																																										
D	2011	CTS	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2011	CTS	Body	Park Assist Module																																																									
D	2011	CTS	Body	Passenger Door Switch																																																									
D	2011	CTS	Body	Passenger Presence System																																																									
D	2011	CTS	Body	Pedestrian Impact Detection Module																																																									
D	2011	CTS	Body	Radio																																																									
D	2011	CTS	Body	Supplemental Inflatable Restraint																																																									
D	2011	CTS	Body	TV Antenna Module																																																									
D	2011	CTS	Body	Vehicle Comm. Interface Module																																																									
D	2011	STS	Powertrain	(D)3.6L V6 LLT Engine Control Module																																																									
D	2011	STS	Powertrain	(D)3.6L V6 LLT Transmission Control Module																																																									
D	2011	STS	Chassis	Electronic Brake Control Module																																																									
D	2011	STS	Chassis	Electronic Suspension Control																																																									
D	2011	STS	Body	Amplifier (Bose)																																																									
D	2011	STS	Body	Digital Radio Receiver																																																									
D	2011	STS	Body	Distance Sensing Cruise Control																																																									
D	2011	STS	Body	Driver Door Module																																																									
D	2011	STS	Body	Driver Door Switch																																																									
D	2011	STS	Body	Driver Position Module																																																									
D	2011	STS	Body	Headlamp Control Module																																																									
D	2011	STS	Body	Head Up Display																																																									
D	2011	STS	Body	HVAC Control Module																																																									
D	2011	STS	Body	Instrument Panel Cluster																																																									
D	2011	STS	Body	Instrument Panel Module																																																									
D	2011	STS	Body	Left Rear Door Module																																																									
D	2011	STS	Body	Left Side Object Detection Module																																																									
D	2011	STS	Body	Passenger Door Module																																																									
D	2011	STS	Body	Uplevel Radio																																																									
D	2011	STS	Body	Navigation Radio																																																									
D	2011	STS	Body	Rear Integration Module																																																									
D	2011	STS	Body	Remote Control Door Lock Receiver																																																										
D	2011	STS	Body	Right Rear Door Module																																																									
D	2011	STS	Body	Right Side Object Detection Module																																																									
D	2011	STS	Body	Supplemental Inflatable Restraint																																																									
D	2011	STS	Body	TV Antenna Module																																																									
D	2011	STS	Body	Vehicle Comm. Interface Module																																																									
D	2011	STS	Body	Veh Direction Alert Alarm Warn Mod																																																									
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																									
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																									
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																									
D	2012	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																									
D	2012	P Type Engine	Chassis	Electronic Brake Control Module																																																									
D	2012	P Type Engine	Chassis	Electronic Suspension Control																																																									
D	2012	P Type Engine	Chassis	Parking Brake Control Module																																																									
D	2012	P Type Engine	Body	Body Control Module																																																									
D	2012	P Type Engine	Body	Body Control Module (aux.)																																																									
D	2012	P Type Engine	Body	Driver Door Switch																																																									
D	2012	P Type Engine	Body	Headlamp Control Module																																																									
D	2012	P Type Engine	Body	HVAC Control Module																																																									
D	2012	P Type Engine	Body	Instrument Panel Cluster																																																									
D	2012	P Type Engine	Body	Left Side Object Detection Module																																																									
D	2012	P Type Engine	Body	Liftgate Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2012	P Type Engine	Body	Memory Seat Module																																																										
D	2012	P Type Engine	Body	Park Assist Module																																																										
D	2012	P Type Engine	Body	Passenger Door Switch																																																										
D	2012	P Type Engine	Body	Passenger Presence System																																																										
D	2012	P Type Engine	Body	Pedestrian Impact Detection Module																																																										
D	2012	P Type Engine	Body	Radio																																																										
D	2012	P Type Engine	Body	Right Side Object Detection Module																																																										
D	2012	P Type Engine	Body	Supplemental Inflatable Restraint																																																										
D	2012	P Type Engine	Body	TV Antenna Module																																																										
D	2012	P Type Engine	Body	Vehicle Comm. Interface Module																																																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto																																																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual																																																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																										
D	2012	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																										
D	2012	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
D	2012	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																										
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																										
D	2012	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																										
D	2012	Other	Chassis	Electronic Brake Control Module																																																										
D	2012	Other	Chassis	Electronic Suspension Control																																																										
D	2012	Other	Chassis	Parking Brake Control Module																																																										
D	2012	Other	Body	Body Control Module																																																										
D	2012	Other	Body	Body Control Module (aux.)																																																										
D	2012	Other	Body	Driver Door Switch																																																										
D	2012	Other	Body	Headlamp Control Module																																																										
D	2012	Other	Body	HVAC Control Module																																																										
D	2012	Other	Body	Instrument Panel Cluster																																																										
D	2012	Other	Body	Left Side Object Detection Module																																																										
D	2012	Other	Body	Liftgate Module																																																										
D	2012	Other	Body	Memory Seat Module																																																										
D	2012	Other	Body	Park Assist Module																																																										
D	2012	Other	Body	Passenger Door Switch																																																										
D	2012	Other	Body	Passenger Presence System																																																										
D	2012	Other	Body	Pedestrian Impact Detection Module																																																										
D	2012	Other	Body	Radio																																																										
D	2012	Other	Body	Right Side Object Detection Module																																																										
D	2012	Other	Body	Supplemental Inflatable Restraint																																																										
D	2012	Other	Body	TV Antenna Module																																																										
D	2012	Other	Body	Vehicle Comm. Interface Module																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Auto																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Engine Control Module Manual																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Fuel Pump Control Module																																																										
D	2013	P Type Engine	Powertrain	(P)6.2L V8 LSA Transmission Control Module																																																										
D	2013	P Type Engine	Chassis	Electronic Brake Control Module																																																										
D	2013	P Type Engine	Chassis	Electronic Suspension Control																																																										
D	2013	P Type Engine	Chassis	Parking Brake Control Module																																																										
D	2013	P Type Engine	Body	Body Control Module																																																										
D	2013	P Type Engine	Body	Body Control Module (aux.)																																																										
D	2013	P Type Engine	Body	Driver Door Switch																																																										
D	2013	P Type Engine	Body	Headlamp Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2013	P Type Engine	Body	HVAC Control Module																																																										
D	2013	P Type Engine	Body	Instrument Panel Cluster																																																											
D	2013	P Type Engine	Body	Left Side Object Detection Module																																																											
D	2013	P Type Engine	Body	Liftgate Module																																																											
D	2013	P Type Engine	Body	Memory Seat Module																																																											
D	2013	P Type Engine	Body	Park Assist Module																																																											
D	2013	P Type Engine	Body	Passenger Door Switch																																																											
D	2013	P Type Engine	Body	Passenger Presence System																																																											
D	2013	P Type Engine	Body	Pedestrian Impact Detection Module																																																											
D	2013	P Type Engine	Body	Radio																																																											
D	2013	P Type Engine	Body	Right Side Object Detection Module																																																											
D	2013	P Type Engine	Body	Supplemental Inflatable Restraint																																																											
D	2013	P Type Engine	Body	TV Antenna Module																																																											
D	2013	P Type Engine	Body	Vehicle Comm. Interface Module																																																											
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Auto																																																											
D	2013	Other	Powertrain	(5)3.0L V6 LFW Engine Control Module Manual																																																											
D	2013	Other	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																											
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																											
D	2013	Other	Powertrain	(5)3.0L V6 LFW Transfer Case Control Module																																																											
D	2013	Other	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																											
D	2013	Other	Powertrain	(3)3.6L V6 LFX Fuel Pump Control Module																																																											
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transmission Control Module																																																											
D	2013	Other	Powertrain	(3)3.6L V6 LFX Transfer Case Control Module																																																											
D	2013	Other	Chassis	Electronic Brake Control Module																																																											
D	2013	Other	Chassis	Electronic Suspension Control																																																											
D	2013	Other	Chassis	Parking Brake Control Module																																																											
D	2013	Other	Body	Body Control Module																																																											
D	2013	Other	Body	Body Control Module (aux.)																																																											
D	2013	Other	Body	Driver Door Switch																																																											
D	2013	Other	Body	Headlamp Control Module																																																											
D	2013	Other	Body	HVAC Control Module																																																											
D	2013	Other	Body	Instrument Panel Cluster																																																											
D	2013	Other	Body	Left Side Object Detection Module																																																											
D	2013	Other	Body	Liftgate Module																																																											
D	2013	Other	Body	Memory Seat Module																																																											
D	2013	Other	Body	Park Assist Module																																																											
D	2013	Other	Body	Passenger Door Switch																																																											
D	2013	Other	Body	Passenger Presence System																																																											
D	2013	Other	Body	Pedestrian Impact Detection Module																																																											
D	2013	Other	Body	Radio																																																											
D	2013	Other	Body	Right Side Object Detection Module																																																											
D	2013	Other	Body	Supplemental Inflatable Restraint																																																											
D	2013	Other	Body	TV Antenna Module																																																											
D	2013	Other	Body	Vehicle Comm. Interface Module																																																											
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
D	2014	CTS	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
D	2014	CTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
D	2014	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
D	2014	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																											
D	2014	CTS	Powertrain	Chassis Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2014	CTS	Powertrain	Transfer Case Control Module																																																										
D	2014	CTS	Chassis	Electronic Brake Control Module																																																											
D	2014	CTS	Chassis	Parking Brake Control Module																																																											
D	2014	CTS	Chassis	Suspension Control Module																																																											
D	2014	CTS	Body	Body Control Module Coupe																																																											
D	2014	CTS	Body	Body Control Module Station Wagon																																																											
D	2014	CTS	Body	Auxiliary Body Control Module																																																											
D	2014	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	CTS	Body	Passenger Presence Module																																																											
D	2014	CTS	Body	Pedestrian Impact Detection Module																																																											
D	2014	CTS	Body	Instrument Cluster																																																											
D	2014	CTS	Body	Headlamp Control Module																																																											
D	2014	CTS	Body	Radio																																																											
D	2014	CTS	Body	Amplifier																																																											
D	2014	CTS	Body	Television Antenna Module																																																											
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2014	CTS	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	CTS	Body	HVAC Control Module																																																											
D	2014	CTS	Body	Driver Door Switch Panel Control Module																																																											
D	2014	CTS	Body	Passenger Door Switch Panel Control Module																																																											
D	2014	CTS	Body	Liftgate Control Module																																																											
D	2014	CTS	Body	Seat Memory Control Module																																																											
D	2014	CTS	Body	Right Side Object Detection Control Module																																																											
D	2014	CTS	Body	Left Side Object Detection Control Module																																																											
D	2014	CTS	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
D	2014	CTS	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
D	2014	CTS	Body	Parking Assist Control Module																																																											
D	2014	CTS	Body	Theft Deterrent Module																																																											
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
D	2015	CTS	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
D	2015	CTS	Powertrain	(P) 6.2L LSA Transmission Control Module																																																											
D	2015	CTS	Powertrain	Chassis Control Module																																																											
D	2015	CTS	Powertrain	Transfer Case Control Module																																																											
D	2015	CTS	Chassis	Electronic Brake Control Module																																																											
D	2015	CTS	Chassis	Parking Brake Control Module																																																											
D	2015	CTS	Chassis	Suspension Control Module																																																											
D	2015	CTS	Body	Body Control Module Coupe																																																											
D	2015	CTS	Body	Body Control Module Station Wagon																																																											
D	2015	CTS	Body	Auxiliary Body Control Module																																																											
D	2015	CTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	CTS	Body	Passenger Presence Module																																																											
D	2015	CTS	Body	Pedestrian Impact Detection Module																																																											
D	2015	CTS	Body	Instrument Cluster																																																											
D	2015	CTS	Body	Headlamp Control Module																																																											
D	2015	CTS	Body	Radio																																																											
D	2015	CTS	Body	Amplifier																																																											
D	2015	CTS	Body	Television Antenna Module																																																											
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2015	CTS	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2015	CTS	Body	HVAC Control Module																																																											
D	2015	CTS	Body	Driver Door Switch Panel Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2015	CTS	Body	Passenger Door Switch Panel Control Module																																																										
D	2015	CTS	Body	Liftgate Control Module																																																											
D	2015	CTS	Body	Seat Memory Control Module																																																											
D	2015	CTS	Body	Right Side Object Detection Control Module																																																											
D	2015	CTS	Body	Left Side Object Detection Control Module																																																											
D	2015	CTS	Body	Remote Control Door Lock Receiver																																																											
D	2015	CTS	Body	Parking Assist Control Module																																																											
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																											
K	2004	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																											
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																											
K	2004	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																											
K	2004	(KD)Deville	Body	Amplifier (Delco)																																																											
K	2004	(KD)Deville	Body	CD Changer																																																											
K	2004	(KD)Deville	Body	Dash Integration Module																																																											
K	2004	(KD)Deville	Body	Digital Radio Receiver																																																											
K	2004	(KD)Deville	Body	Driver Door Switch																																																											
K	2004	(KD)Deville	Body	Driver Door Module																																																											
K	2004	(KD)Deville	Body	Passenger Door Module																																																											
K	2004	(KD)Deville	Body	Left Rear Door Module																																																											
K	2004	(KD)Deville	Body	Right Rear Door Module																																																											
K	2004	(KD)Deville	Body	Instrument Panel Cluster																																																											
K	2004	(KD)Deville	Body	Instrument Panel Module																																																											
K	2004	(KD)Deville	Body	Memory Seat Module																																																											
K	2004	(KD)Deville	Body	Navigation Radio																																																											
K	2004	(KD)Deville	Body	Radio																																																											
K	2004	(KD)Deville	Body	Rear Climate Control Panel																																																											
K	2004	(KD)Deville	Body	Rear Integration Module																																																											
K	2004	(KD)Deville	Body	Remote Function Actuation																																																											
K	2004	(KD)Deville	Body	Supplemental Inflatable Restraint																																																											
K	2004	(KD)Deville	Body	Tilt Telescope Module																																																											
K	2004	(KD)Deville	Body	Vehicle Theft Deterrent																																																											
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																											
K	2004	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																											
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																											
K	2004	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																											
K	2004	(KE)DHS	Body	Amplifier (Bose)																																																											
K	2004	(KE)DHS	Body	CD Changer																																																											
K	2004	(KE)DHS	Body	Dash Integration Module																																																											
K	2004	(KE)DHS	Body	Digital Radio Receiver																																																											
K	2004	(KE)DHS	Body	Driver Door Switch																																																											
K	2004	(KE)DHS	Body	Driver Door Module																																																											
K	2004	(KE)DHS	Body	Passenger Door Module																																																											
K	2004	(KE)DHS	Body	Left Rear Door Module																																																											
K	2004	(KE)DHS	Body	Right Rear Door Module																																																											
K	2004	(KE)DHS	Body	Instrument Panel Cluster																																																											
K	2004	(KE)DHS	Body	Instrument Panel Module																																																											
K	2004	(KE)DHS	Body	Memory Seat Module																																																											
K	2004	(KE)DHS	Body	Navigation Radio																																																											
K	2004	(KE)DHS	Body	Radio																																																											
K	2004	(KE)DHS	Body	Rear Climate Control Panel																																																											
K	2004	(KE)DHS	Body	Rear Integration Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2004	(KE)DHS	Body	Remote Function Actuation																																																										
K	2004	(KE)DHS	Body	Supplemental Inflatable Restraint																																																										
K	2004	(KE)DHS	Body	Tilt Telescope Module																																																										
K	2004	(KE)DHS	Body	Vehicle Theft Deterrent																																																										
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2004	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2004	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2004	(KF)DTS	Body	Amplifier (Bose)																																																										
K	2004	(KF)DTS	Body	CD Changer																																																										
K	2004	(KF)DTS	Body	Dash Integration Module																																																										
K	2004	(KF)DTS	Body	Digital Radio Receiver																																																										
K	2004	(KF)DTS	Body	Driver Door Switch																																																										
K	2004	(KF)DTS	Body	Driver Door Module																																																										
K	2004	(KF)DTS	Body	Passenger Door Module																																																										
K	2004	(KF)DTS	Body	Left Rear Door Module																																																										
K	2004	(KF)DTS	Body	Right Rear Door Module																																																										
K	2004	(KF)DTS	Body	Instrument Panel Cluster																																																										
K	2004	(KF)DTS	Body	Instrument Panel Module																																																										
K	2004	(KF)DTS	Body	Memory Seat Module																																																										
K	2004	(KF)DTS	Body	Navigation Radio																																																										
K	2004	(KF)DTS	Body	Radio																																																										
K	2004	(KF)DTS	Body	Rear Climate Control Panel																																																										
K	2004	(KF)DTS	Body	Rear Integration Module																																																										
K	2004	(KF)DTS	Body	Remote Function Actuation																																																										
K	2004	(KF)DTS	Body	Supplemental Inflatable Restraint																																																										
K	2004	(KF)DTS	Body	Tilt Telescope Module																																																										
K	2004	(KF)DTS	Body	Vehicle Theft Deterrent																																																										
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2004	(KS)Seville SLS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2004	(KS)Seville SLS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2004	(KS)Seville SLS	Body	Amplifier (Bose)																																																										
K	2004	(KS)Seville SLS	Body	Amplifier (Delco)																																																										
K	2004	(KS)Seville SLS	Body	CD Changer																																																										
K	2004	(KS)Seville SLS	Body	Dash Integration Module																																																										
K	2004	(KS)Seville SLS	Body	Digital Radio Receiver																																																										
K	2004	(KS)Seville SLS	Body	Driver Door Module																																																										
K	2004	(KS)Seville SLS	Body	Instrument Panel Cluster																																																										
K	2004	(KS)Seville SLS	Body	Instrument Panel Module																																																										
K	2004	(KS)Seville SLS	Body	Memory Seat Module																																																										
K	2004	(KS)Seville SLS	Body	Navigation Radio																																																										
K	2004	(KS)Seville SLS	Body	Radio																																																										
K	2004	(KS)Seville SLS	Body	Rear Integration Module																																																										
K	2004	(KS)Seville SLS	Body	Remote Function Actuation																																																										
K	2004	(KS)Seville SLS	Body	Supplemental Inflatable Restraint																																																										
K	2004	(KS)Seville SLS	Body	Tilt Telescope Module																																																										
K	2004	(KS)Seville SLS	Body	Vehicle Theft Deterrent																																																										
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2004	(KY)Seville STS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2004	(KY)Seville STS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																									
K	2004	(KY)Seville STS	Body	Amplifier (Bose)																																																										
K	2004	(KY)Seville STS	Body	Amplifier (Delco)																																																										
K	2004	(KY)Seville STS	Body	CD Changer																																																										
K	2004	(KY)Seville STS	Body	Dash Integration Module																																																										
K	2004	(KY)Seville STS	Body	Digital Radio Receiver																																																										
K	2004	(KY)Seville STS	Body	Driver Door Module																																																										
K	2004	(KY)Seville STS	Body	Instrument Panel Cluster																																																										
K	2004	(KY)Seville STS	Body	Instrument Panel Module																																																										
K	2004	(KY)Seville STS	Body	Memory Seat Module																																																										
K	2004	(KY)Seville STS	Body	Navigation Radio																																																										
K	2004	(KY)Seville STS	Body	Radio																																																										
K	2004	(KY)Seville STS	Body	Rear Integration Module																																																										
K	2004	(KY)Seville STS	Body	Remote Function Actuation																																																										
K	2004	(KY)Seville STS	Body	Supplemental Inflatable Restraint																																																										
K	2004	(KY)Seville STS	Body	Tilt Telescope Module																																																										
K	2004	(KY)Seville STS	Body	Vehicle Theft Deterrent																																																										
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2005	(KD)Deville	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2005	(KD)Deville	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2005	(KD)Deville	Body	Amplifier (Delco)																																																										
K	2005	(KD)Deville	Body	CD Changer																																																										
K	2005	(KD)Deville	Body	Dash Integration Module																																																										
K	2005	(KD)Deville	Body	Digital Radio Receiver																																																										
K	2005	(KD)Deville	Body	Driver Door Switch																																																										
K	2005	(KD)Deville	Body	Driver Door Module																																																										
K	2005	(KD)Deville	Body	Passenger Door Module																																																										
K	2005	(KD)Deville	Body	Left Rear Door Module																																																										
K	2005	(KD)Deville	Body	Right Rear Door Module																																																										
K	2005	(KD)Deville	Body	Instrument Panel Cluster																																																										
K	2005	(KD)Deville	Body	Instrument Panel Module																																																										
K	2005	(KD)Deville	Body	Memory Seat Module																																																										
K	2005	(KD)Deville	Body	Navigation Radio																																																										
K	2005	(KD)Deville	Body	Radio																																																										
K	2005	(KD)Deville	Body	Rear Climate Control Panel																																																										
K	2005	(KD)Deville	Body	Rear Integration Module																																																										
K	2005	(KD)Deville	Body	Remote Function Actuation																																																										
K	2005	(KD)Deville	Body	Supplemental Inflatable Restraint																																																										
K	2005	(KD)Deville	Body	Tilt Telescope Module																																																										
K	2005	(KD)Deville	Body	Vehicle Theft Deterrent																																																										
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2005	(KE)DHS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2005	(KE)DHS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2005	(KE)DHS	Body	Amplifier (Bose)																																																										
K	2005	(KE)DHS	Body	CD Changer																																																										
K	2005	(KE)DHS	Body	Dash Integration Module																																																										
K	2005	(KE)DHS	Body	Digital Radio Receiver																																																										
K	2005	(KE)DHS	Body	Driver Door Switch																																																										
K	2005	(KE)DHS	Body	Driver Door Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2005	(KE)DHS	Body	Passenger Door Module																																																									
K	2005	(KE)DHS	Body	Left Rear Door Module																																																										
K	2005	(KE)DHS	Body	Right Rear Door Module																																																										
K	2005	(KE)DHS	Body	Instrument Panel Cluster																																																										
K	2005	(KE)DHS	Body	Instrument Panel Module																																																										
K	2005	(KE)DHS	Body	Memory Seat Module																																																										
K	2005	(KE)DHS	Body	Navigation Radio																																																										
K	2005	(KE)DHS	Body	Radio																																																										
K	2005	(KE)DHS	Body	Rear Climate Control Panel																																																										
K	2005	(KE)DHS	Body	Rear Integration Module																																																										
K	2005	(KE)DHS	Body	Remote Function Actuation																																																										
K	2005	(KE)DHS	Body	Supplemental Inflatable Restraint																																																										
K	2005	(KE)DHS	Body	Tilt Telescope Module																																																										
K	2005	(KE)DHS	Body	Vehicle Theft Deterrent																																																										
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Engine Control Module																																																										
K	2005	(KF)DTS	Powertrain	(9)4.6L V8 L37 Transmission Control Module																																																										
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Engine Control Module																																																										
K	2005	(KF)DTS	Powertrain	(Y)4.6L V8 LD8 Transmission Control Module																																																										
K	2005	(KF)DTS	Body	Amplifier (Bose)																																																										
K	2005	(KF)DTS	Body	CD Changer																																																										
K	2005	(KF)DTS	Body	Dash Integration Module																																																										
K	2005	(KF)DTS	Body	Digital Radio Receiver																																																										
K	2005	(KF)DTS	Body	Driver Door Switch																																																										
K	2005	(KF)DTS	Body	Driver Door Module																																																										
K	2005	(KF)DTS	Body	Passenger Door Module																																																										
K	2005	(KF)DTS	Body	Left Rear Door Module																																																										
K	2005	(KF)DTS	Body	Right Rear Door Module																																																										
K	2005	(KF)DTS	Body	Instrument Panel Cluster																																																										
K	2005	(KF)DTS	Body	Instrument Panel Module																																																										
K	2005	(KF)DTS	Body	Memory Seat Module																																																										
K	2005	(KF)DTS	Body	Navigation Radio																																																										
K	2005	(KF)DTS	Body	Radio																																																										
K	2005	(KF)DTS	Body	Rear Climate Control Panel																																																										
K	2005	(KF)DTS	Body	Rear Integration Module																																																										
K	2005	(KF)DTS	Body	Remote Function Actuation																																																										
K	2005	(KF)DTS	Body	Supplemental Inflatable Restraint																																																										
K	2005	(KF)DTS	Body	Tilt Telescope Module																																																										
K	2005	(KF)DTS	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Powertrain	Engine Control Module																																																										
K	2006	ALL	Powertrain	Automatic Transaxle																																																										
K	2006	ALL	Chassis	Antilock Brake System																																																										
K	2006	ALL	Body	Amplifier (Bose)																																																										
K	2006	ALL	Body	Aux. HVAC Control Module																																																										
K	2006	ALL	Body	Body Control Module																																																										
K	2006	ALL	Body	Digital Radio Receiver																																																										
K	2006	ALL	Body	Distance Sensing Cruise Control																																																										
K	2006	ALL	Body	Driver Door Switch																																																										
K	2006	ALL	Body	Driver Position Module																																																										
K	2006	ALL	Body	HVAC Control Module																																																										
K	2006	ALL	Body	Instrument Panel Cluster																																																										
K	2006	ALL	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2006	ALL	Body	Passenger Door Switch																																																									
K	2006	ALL	Body	Passenger Presence System																																																									
K	2006	ALL	Body	Radio																																																									
K	2006	ALL	Body	Rear Heated Seat Module																																																									
K	2006	ALL	Body	Remote Control Door Lock Receiver																																																									
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2006	ALL	Body	Theft Deterrent Module																																																									
K	2006	ALL	Body	TV Antenna Module																																																									
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2007	ALL	Powertrain	Engine Control Module																																																									
K	2007	ALL	Powertrain	Transmission Control Module																																																									
K	2007	ALL	Chassis	Electronic Brake Control Module																																																									
K	2007	ALL	Body	Amplifier (Bose)																																																									
K	2007	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																									
K	2007	ALL	Body	Body Control Module																																																									
K	2007	ALL	Body	Digital Radio Receiver																																																									
K	2007	ALL	Body	Distance Sensing Cruise Control																																																									
K	2007	ALL	Body	Driver Door Switch																																																									
K	2007	ALL	Body	Driver Position Module																																																									
K	2007	ALL	Body	CJ2 Dual Zone HVAC Auto																																																									
K	2007	ALL	Body	CJ4 Tri Zone HVAC Auto																																																									
K	2007	ALL	Body	Inside Rear View Mirror Module																																																									
K	2007	ALL	Body	Instrument Panel Cluster																																																									
K	2007	ALL	Body	Park Assist Module																																																									
K	2007	ALL	Body	Passenger Door Switch																																																									
K	2007	ALL	Body	Passenger Presence System																																																									
K	2007	ALL	Body	Radio																																																									
K	2007	ALL	Body	Rear Heated Seat Module																																																									
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2007	ALL	Body	Theft Deterrent Module																																																									
K	2007	ALL	Body	TV Antenna Module																																																									
K	2007	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2008	ALL	Powertrain	Engine Control Module																																																									
K	2008	ALL	Powertrain	Transmission Control Module																																																									
K	2008	ALL	Chassis	Electronic Brake Control Module																																																									
K	2008	ALL	Body	Amplifier (Bose)																																																									
K	2008	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																									
K	2008	ALL	Body	Body Control Module																																																									
K	2008	ALL	Body	Digital Radio Receiver																																																									
K	2008	ALL	Body	Distance Sensing Cruise Control																																																									
K	2008	ALL	Body	Driver Door Switch																																																									
K	2008	ALL	Body	Driver Position Module																																																									
K	2008	ALL	Body	CJ2 Dual Zone HVAC Auto																																																									
K	2008	ALL	Body	CJ4 Tri Zone HVAC Auto																																																									
K	2008	ALL	Body	Inside Rear View Mirror Module																																																									
K	2008	ALL	Body	Instrument Panel Cluster																																																									
K	2008	ALL	Body	Left Side Object Detection Module																																																									
K	2008	ALL	Body	Park Assist Module																																																									
K	2008	ALL	Body	Passenger Door Switch																																																									
K	2008	ALL	Body	Passenger Presence System																																																									
K	2008	ALL	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2008	ALL	Body	Rear Heated Seat Module																																																									
K	2008	ALL	Body	Right Side Object Detection Module																																																									
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2008	ALL	Body	Theft Deterrent Module																																																									
K	2008	ALL	Body	TV Antenna Module																																																									
K	2008	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2008	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																									
K	2009	ALL	Powertrain	Engine Control Module																																																									
K	2009	ALL	Powertrain	Transmission Control Module																																																									
K	2009	ALL	Chassis	Electronic Brake Control Module																																																									
K	2009	ALL	Body	Amplifier (Bose)																																																									
K	2009	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																									
K	2009	ALL	Body	Body Control Module																																																									
K	2009	ALL	Body	Digital Radio Receiver																																																									
K	2009	ALL	Body	Distance Sensing Cruise Control																																																									
K	2009	ALL	Body	Driver Door Switch																																																									
K	2009	ALL	Body	Driver Position Module																																																									
K	2009	ALL	Body	CJ2 Dual Zone HVAC Auto																																																									
K	2009	ALL	Body	CJ4 Tri Zone HVAC Auto																																																									
K	2009	ALL	Body	Inside Rear View Mirror Module																																																									
K	2009	ALL	Body	Instrument Panel Cluster																																																									
K	2009	ALL	Body	Left Side Object Detection Module																																																									
K	2009	ALL	Body	Park Assist Module																																																									
K	2009	ALL	Body	Passenger Door Switch																																																									
K	2009	ALL	Body	Passenger Presence System																																																									
K	2009	ALL	Body	Radio																																																									
K	2009	ALL	Body	Rear Heated Seat Module																																																									
K	2009	ALL	Body	Right Side Object Detection Module																																																									
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2009	ALL	Body	Theft Deterrent Module																																																									
K	2009	ALL	Body	TV Antenna Module																																																									
K	2009	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2009	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2009	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																									
K	2010	ALL	Powertrain	Engine Control Module																																																									
K	2010	ALL	Powertrain	Transmission Control Module																																																									
K	2010	ALL	Chassis	Electronic Brake Control Module																																																									
K	2010	ALL	Body	Amplifier (Bose)																																																									
K	2010	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																									
K	2010	ALL	Body	Body Control Module																																																									
K	2010	ALL	Body	Digital Radio Receiver																																																									
K	2010	ALL	Body	Distance Sensing Cruise Control																																																									
K	2010	ALL	Body	Driver Door Switch																																																									
K	2010	ALL	Body	Driver Position Module																																																									
K	2010	ALL	Body	CJ2 Dual Zone HVAC Auto																																																									
K	2010	ALL	Body	CJ4 Tri Zone HVAC Auto																																																									
K	2010	ALL	Body	Inside Rear View Mirror Module																																																									
K	2010	ALL	Body	Instrument Panel Cluster																																																									
K	2010	ALL	Body	Left Side Object Detection Module																																																									
K	2010	ALL	Body	Park Assist Module																																																									
K	2010	ALL	Body	Passenger Door Switch																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2010	ALL	Body	Passenger Presence System																																																												
K	2010	ALL	Body	Radio																																																												
K	2010	ALL	Body	Rear Heated Seat Module																																																													
K	2010	ALL	Body	Right Side Object Detection Module																																																													
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																													
K	2010	ALL	Body	Theft Deterrent Module																																																													
K	2010	ALL	Body	TV Antenna Module																																																													
K	2010	ALL	Body	Vehicle Comm. Interface Module																																																													
K	2010	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																													
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Engine Control Module																																																													
K	2011	ALL	Powertrain	(S)4.6L V8 L37 Transmission Control Module																																																													
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Engine Control Module																																																													
K	2011	ALL	Powertrain	(6)4.6L V8 LD8 Transmission Control Module																																																													
K	2011	ALL	Chassis	Electronic Brake Control Module																																																													
K	2011	ALL	Body	Amplifier (Bose)																																																													
K	2011	ALL	Body	Aux. HVAC Control Module(CJ4 HVAC Only)																																																													
K	2011	ALL	Body	Body Control Module																																																													
K	2011	ALL	Body	Digital Radio Receiver																																																													
K	2011	ALL	Body	Distance Sensing Cruise Control																																																													
K	2011	ALL	Body	Driver Door Switch																																																													
K	2011	ALL	Body	Driver Position Module																																																													
K	2011	ALL	Body	CJ2 Dual Zone HVAC Auto																																																													
K	2011	ALL	Body	CJ4 Tri Zone HVAC Auto																																																													
K	2011	ALL	Body	Inside Rear View Mirror Module																																																													
K	2011	ALL	Body	Instrument Panel Cluster																																																													
K	2011	ALL	Body	Left Side Object Detection Module																																																													
K	2011	ALL	Body	Park Assist Module																																																													
K	2011	ALL	Body	Passenger Door Switch																																																													
K	2011	ALL	Body	Passenger Presence System																																																													
K	2011	ALL	Body	Radio																																																												
K	2011	ALL	Body	Rear Heated Seat Module																																																													
K	2011	ALL	Body	Right Side Object Detection Module																																																													
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																													
K	2011	ALL	Body	Theft Deterrent Module																																																													
K	2011	ALL	Body	TV Antenna Module																																																													
K	2011	ALL	Body	Vehicle Comm. Interface Module																																																													
K	2011	ALL	Body	Veh Direction Alert Alarm Warn Mod																																																													
K	2016	CT6	Powertrain	(X) 2.0L LTG Engine Control Module																																																													
K	2016	CT6	Powertrain	(X) 2.0L LTG Transmission Control Module																																																													
K	2016	CT6	Powertrain	(6) 3.0L LGW Engine Control Module																																																													
K	2016	CT6	Powertrain	(6) 3.0L LGW Transmission Control Module																																																													
K	2016	CT6	Powertrain	(S) 3.6L LGX Engine Control Module																																																													
K	2016	CT6	Powertrain	(S) 3.6L LGX Transmission Control Module																																																													
K	2016	CT6	Powertrain	Transfer Case Control Module																																																													
K	2016	CT6	Chassis	Electronic Brake Control Module																																																													
K	2016	CT6	Chassis	Brake Booster Control Module																																																													
K	2016	CT6	Chassis	Power Steering Control Module																																																													
K	2016	CT6	Chassis	Rear Wheel Steering Control Module																																																													
K	2016	CT6	Chassis	Suspension Control Module																																																													
K	2016	CT6	Body	Body Control Module																																																													
K	2016	CT6	Body	Serial Data Gateway Module																																																													

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2016	CT6	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2016	CT6	Body	Passenger Presence Module																																																										
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Left																																																										
K	2016	CT6	Body	Seat Belt Retractor Motor Module - Right																																																										
K	2016	CT6	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
K	2016	CT6	Body	Instrument Cluster Full Screen Display (UDV)																																																										
K	2016	CT6	Body	Radio Controls																																																										
K	2016	CT6	Body	HVAC Controls																																																										
K	2016	CT6	Body	Active Safety Control Module																																																										
K	2016	CT6	Body	Video Processing Control Module																																																										
K	2016	CT6	Body	Headlamp Control Module																																																										
K	2016	CT6	Body	Trailer Interface Control Module																																																										
K	2016	CT6	Body	Radio																																																										
K	2016	CT6	Body	Amplifier																																																										
K	2016	CT6	Body	Infotainment Control Touchpad																																																										
K	2016	CT6	Body	Human Machine Interface Control Module																																																										
K	2016	CT6	Body	Navigation Control Module																																																										
K	2016	CT6	Body	Telematics Communication Interface Control Module																																																										
K	2016	CT6	Body	HVAC Control Module																																																										
K	2016	CT6	Body	Liftgate Control Module																																																										
K	2016	CT6	Body	Seat Memory Control Module - Passenger																																																										
K	2016	CT6	Body	Seat Memory Control Module - Left Rear																																																										
K	2016	CT6	Body	Seat Memory Control Module - Driver																																																										
K	2016	CT6	Body	Seat Memory Control Module - Right Rear																																																										
K	2016	CT6	Body	Keyless Entry Control Module																																																										
K	2016	CT6	Body	Left Side Object Detection Control Module																																																										
K	2016	CT6	Body	Parking Assist Control Module																																																										
K	2016	CT6	Body	Frontview Camera Module																																																										
K	2016	CT6	Body	Long Range Radar Sensor Module																																																										
K	2016	CT6	Body	Left Front Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Right Front Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Rear Short Range Radar Sensor Module																																																										
K	2016	CT6	Body	Night Vision Camera Control Module																																																										
R	2014	ELR	Powertrain	Engine Control Module																																																										
R	2014	ELR	Powertrain	Trasmission Control Module																																																										
R	2014	ELR	Powertrain	Chassis Control Module																																																										
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module																																																										
R	2014	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2014	ELR	Powertrain	Drive Motor Control Module 1																																																										
R	2014	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2014	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2014	ELR	Chassis	Electronic Brake Control Module																																																										
R	2014	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2014	ELR	Chassis	Parking Brake Control Module																																																										
R	2014	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2014	ELR	Chassis	Power Steering Control Module																																																										
R	2014	ELR	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2014	ELR	Chassis	Suspension Control Module																																																										
R	2014	ELR	Body	Body Control Module																																																										
R	2014	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2014	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2014	ELR	Body	Passenger Presence Module																																																									
R	2014	ELR	Body	Instrument Cluster																																																									
R	2014	ELR	Body	Radio/HVAC Control																																																									
R	2014	ELR	Body	Radio																																																									
R	2014	ELR	Body	Amplifier																																																									
R	2014	ELR	Body	Human Machine Interface Control Module																																																										
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	ELR	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	ELR	Body	HVAC Control Module																																																										
R	2014	ELR	Body	Electric A/C Compressor Control Module																																																										
R	2014	ELR	Body	Coolant Heater Control Module																																																										
R	2014	ELR	Body	Seat Memory Control Module - Driver																																																										
R	2014	ELR	Body	Keyless Entry Control Module																																																										
R	2014	ELR	Body	Right Side Object Detection Control Module																																																										
R	2014	ELR	Body	Left Side Object Detection Control Module																																																										
R	2014	ELR	Body	Parking Assist Control Module																																																										
R	2014	ELR	Body	Frontview Camera Module																																																										
R	2014	ELR	Body	Steering Column Lock Control Module																																																										
R	2014	ELR	Body	Battery Charger Control Module																																																										
R	2014	ELR	Body	Battery Energy Control Module																																																										
R	2015	ELR	Powertrain	Engine Control Module																																																										
R	2015	ELR	Powertrain	Trasmission Control Module																																																										
R	2015	ELR	Powertrain	Chassis Control Module																																																										
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module																																																										
R	2015	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2015	ELR	Powertrain	Drive Motor Control Module 1																																																										
R	2015	ELR	Powertrain	Drive Motor Control Module 2																																																										
R	2015	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2015	ELR	Chassis	Electronic Brake Control Module																																																										
R	2015	ELR	Chassis	Distance Sensing Cruise Control Module																																																										
R	2015	ELR	Chassis	Parking Brake Control Module																																																										
R	2015	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2015	ELR	Chassis	Power Steering Control Module																																																										
R	2015	ELR	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2015	ELR	Chassis	Suspension Control Module																																																										
R	2015	ELR	Body	Body Control Module																																																										
R	2015	ELR	Body	Pedestrian Impact Detection Module																																																										
R	2015	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	ELR	Body	Passenger Presence Module																																																										
R	2015	ELR	Body	Instrument Cluster																																																										
R	2015	ELR	Body	Radio/HVAC Control																																																										
R	2015	ELR	Body	Headlamp Control Module																																																										
R	2015	ELR	Body	Radio																																																										
R	2015	ELR	Body	Amplifier																																																										
R	2015	ELR	Body	Human Machine Interface Control Module																																																										
R	2015	ELR	Body	Telematics Communication Interface Control Module																																																										
R	2015	ELR	Body	HVAC Control Module																																																										
R	2015	ELR	Body	Electric A/C Compressor Control Module																																																										
R	2015	ELR	Body	Coolant Heater Control Module																																																										
R	2015	ELR	Body	Seat Memory Control Module - Driver																																																										
R	2015	ELR	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2015	ELR	Body	Right Side Object Detection Control Module																																																												
R	2015	ELR	Body	Left Side Object Detection Control Module																																																												
R	2015	ELR	Body	Parking Assist Control Module																																																												
R	2015	ELR	Body	Frontview Camera Module																																																												
R	2015	ELR	Body	Steering Column Lock Control Module																																																												
R	2015	ELR	Body	Battery Charger Control Module																																																												
R	2015	ELR	Body	Battery Energy Control Module																																																												
R	2016	ELR	Powertrain	Engine Control Module																																																												
R	2016	ELR	Powertrain	Trasmission Control Module																																																												
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module																																																												
R	2016	ELR	Powertrain	Hybrid Powertrain Control Module 2																																																												
R	2016	ELR	Powertrain	Drive Motor Control Module 1																																																												
R	2016	ELR	Powertrain	Drive Motor Control Module 2																																																												
R	2016	ELR	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2016	ELR	Chassis	Electronic Brake Control Module																																																												
R	2016	ELR	Chassis	Distance Sensing Cruise Control Module																																																												
R	2016	ELR	Chassis	Parking Brake Control Module																																																												
R	2016	ELR	Chassis	Multi-Axis Acceleration Sensor Module																																																												
R	2016	ELR	Chassis	Power Steering Control Module																																																												
R	2016	ELR	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2016	ELR	Chassis	Suspension Control Module																																																												
R	2016	ELR	Body	Body Control Module																																																											
R	2016	ELR	Body	Pedestrian Impact Detection Module																																																												
R	2016	ELR	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2016	ELR	Body	Passenger Presence Module																																																											
R	2016	ELR	Body	Instrument Cluster																																																											
R	2016	ELR	Body	Radio/HVAC Control																																																											
R	2016	ELR	Body	Headlamp Control Module																																																											
R	2016	ELR	Body	Radio																																																											
R	2016	ELR	Body	Amplifier																																																											
R	2016	ELR	Body	Human Machine Interface Control Module																																																											
R	2016	ELR	Body	Telematics Communication Interface Control Module																																																											
R	2016	ELR	Body	HVAC Control Module																																																											
R	2016	ELR	Body	Electric A/C Compressor Control Module																																																											
R	2016	ELR	Body	Coolant Heater Control Module																																																											
R	2016	ELR	Body	Seat Memory Control Module - Driver																																																											
R	2016	ELR	Body	Keyless Entry Control Module																																																											
R	2016	ELR	Body	Left Side Object Detection Control Module																																																											
R	2016	ELR	Body	Parking Assist Control Module																																																											
R	2016	ELR	Body	Frontview Camera Module																																																											
R	2016	ELR	Body	Steering Column Lock Control Module																																																											
R	2016	ELR	Body	Battery Charger Control Module																																																											
R	2016	ELR	Body	Battery Energy Control Module																																																											
Y	2004	ALL	Powertrain	Engine Control Module																																																											
Y	2004	ALL	Powertrain	Automatic Transmission																																																											
Y	2004	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2004	ALL	Chassis	Electronic Suspension Control																																																											
Y	2004	ALL	Chassis	Steering Wheel and Column																																																											
Y	2004	ALL	Body	Amplifier (Bose)																																																											
Y	2004	ALL	Body	Body Control Module																																																											
Y	2004	ALL	Body	CD Changer																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Y	2004	ALL	Body	Digital Radio Receiver																																																									
Y	2004	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2004	ALL	Body	Driver Door Module																																																										
Y	2004	ALL	Body	Driver Door Switch																																																										
Y	2004	ALL	Body	Driver Position Module																																																										
Y	2004	ALL	Body	Folding Top Module																																																										
Y	2004	ALL	Body	Head Up Display																																																										
Y	2004	ALL	Body	HVAC Control Module																																																										
Y	2004	ALL	Body	Instrument Panel Cluster																																																										
Y	2004	ALL	Body	Navigation Radio																																																										
Y	2004	ALL	Body	Passenger Door Module																																																										
Y	2004	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2004	ALL	Body	Steering Column Lock Module																																																										
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2005	ALL	Powertrain	Engine Control Module																																																										
Y	2005	ALL	Powertrain	Automatic Transmission																																																										
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2005	ALL	Chassis	Electronic Suspension Control																																																										
Y	2005	ALL	Chassis	Steering Wheel and Column																																																										
Y	2005	ALL	Body	Amplifier (Bose)																																																										
Y	2005	ALL	Body	Body Control Module																																																										
Y	2005	ALL	Body	CD Changer																																																										
Y	2005	ALL	Body	Digital Radio Receiver																																																										
Y	2005	ALL	Body	Distance Sensing Cruise Control																																																										
Y	2005	ALL	Body	Driver Door Module																																																										
Y	2005	ALL	Body	Driver Door Switch																																																										
Y	2005	ALL	Body	Driver Position Module																																																										
Y	2005	ALL	Body	Folding Top Module																																																										
Y	2005	ALL	Body	Head Up Display																																																										
Y	2005	ALL	Body	HVAC Control Module																																																										
Y	2005	ALL	Body	Instrument Panel Cluster																																																										
Y	2005	ALL	Body	Navigation Radio																																																										
Y	2005	ALL	Body	Passenger Door Module																																																										
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2005	ALL	Body	Steering Column Lock Module																																																										
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2006	(YV)XLR	Powertrain	Engine Control Module																																																										
Y	2006	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																										
Y	2006	(YV)XLR	Powertrain	Automatic Transmission																																																										
Y	2006	(YV)XLR	Chassis	Electronic Brake Control Module																																																										
Y	2006	(YV)XLR	Chassis	Electronic Suspension Control																																																										
Y	2006	(YV)XLR	Chassis	Steering Wheel and Column																																																										
Y	2006	(YV)XLR	Body	Amplifier (Bose)																																																										
Y	2006	(YV)XLR	Body	Body Control Module																																																										
Y	2006	(YV)XLR	Body	CD Changer																																																										
Y	2006	(YV)XLR	Body	Digital Radio Receiver																																																										
Y	2006	(YV)XLR	Body	Distance Sensing Cruise Control																																																										
Y	2006	(YV)XLR	Body	Driver Door Module																																																										
Y	2006	(YV)XLR	Body	Driver Door Switch																																																										
Y	2006	(YV)XLR	Body	Driver Position Module																																																										
Y	2006	(YV)XLR	Body	Folding Top Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Y	2006	(YV)XLR	Body	Headlamp Control Module																																																										
Y	2006	(YV)XLR	Body	Head Up Display																																																											
Y	2006	(YV)XLR	Body	HVAC Control Module																																																											
Y	2006	(YV)XLR	Body	Instrument Panel Cluster																																																											
Y	2006	(YV)XLR	Body	Navigation Radio																																																											
Y	2006	(YV)XLR	Body	Passenger Door Module																																																											
Y	2006	(YV)XLR	Body	Remote Control Door Lock Receiver																																																											
Y	2006	(YV)XLR	Body	Steering Column Lock Module																																																											
Y	2006	(YV)XLR	Body	Supplemental Inflatable Restraint																																																											
Y	2006	(YX)XLR-V	Powertrain	Engine Control Module																																																											
Y	2006	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																											
Y	2006	(YX)XLR-V	Powertrain	Automatic Transmission																																																											
Y	2006	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																											
Y	2006	(YX)XLR-V	Chassis	Electronic Suspension Control																																																											
Y	2006	(YX)XLR-V	Chassis	Steering Wheel and Column																																																											
Y	2006	(YX)XLR-V	Body	Amplifier (Bose)																																																											
Y	2006	(YX)XLR-V	Body	Body Control Module																																																											
Y	2006	(YX)XLR-V	Body	CD Changer																																																											
Y	2006	(YX)XLR-V	Body	Digital Radio Receiver																																																											
Y	2006	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																											
Y	2006	(YX)XLR-V	Body	Driver Door Module																																																											
Y	2006	(YX)XLR-V	Body	Driver Door Switch																																																											
Y	2006	(YX)XLR-V	Body	Driver Position Module																																																											
Y	2006	(YX)XLR-V	Body	Folding Top Module																																																											
Y	2006	(YX)XLR-V	Body	Headlamp Control Module																																																											
Y	2006	(YX)XLR-V	Body	Head Up Display																																																											
Y	2006	(YX)XLR-V	Body	HVAC Control Module																																																											
Y	2006	(YX)XLR-V	Body	Instrument Panel Cluster																																																											
Y	2006	(YX)XLR-V	Body	Navigation Radio																																																											
Y	2006	(YX)XLR-V	Body	Passenger Door Module																																																											
Y	2006	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																																											
Y	2006	(YX)XLR-V	Body	Steering Column Lock Module																																																											
Y	2006	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																											
Y	2007	(YV)XLR	Powertrain	Engine Control Module																																																											
Y	2007	(YV)XLR	Powertrain	Exhaust Flow Control Module																																																											
Y	2007	(YV)XLR	Powertrain	Transmission Control Module																																																											
Y	2007	(YV)XLR	Chassis	Electronic Brake Control Module																																																											
Y	2007	(YV)XLR	Chassis	Electronic Suspension Control																																																											
Y	2007	(YV)XLR	Body	Amplifier (Bose)																																																											
Y	2007	(YV)XLR	Body	Body Control Module																																																											
Y	2007	(YV)XLR	Body	CD Changer																																																											
Y	2007	(YV)XLR	Body	Digital Radio Receiver																																																											
Y	2007	(YV)XLR	Body	Distance Sensing Cruise Control																																																											
Y	2007	(YV)XLR	Body	Driver Door Module																																																											
Y	2007	(YV)XLR	Body	Driver Door Switch																																																											
Y	2007	(YV)XLR	Body	Driver Position Module																																																											
Y	2007	(YV)XLR	Body	Folding Top Module																																																											
Y	2007	(YV)XLR	Body	Headlamp Control Module																																																											
Y	2007	(YV)XLR	Body	Head Up Display																																																											
Y	2007	(YV)XLR	Body	HVAC Control Module																																																											
Y	2007	(YV)XLR	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Y	2007	(YV)XLR	Body	Navigation Radio																																																										
Y	2007	(YV)XLR	Body	Passenger Door Module																																																											
Y	2007	(YV)XLR	Body	Remote Control Door Lock Receiver																																																											
Y	2007	(YV)XLR	Body	Steering Column Lock Module																																																											
Y	2007	(YV)XLR	Body	Supplemental Inflatable Restraint																																																											
Y	2007	(YX)XLR-V	Powertrain	Engine Control Module																																																											
Y	2007	(YX)XLR-V	Powertrain	Exhaust Flow Control Module																																																											
Y	2007	(YX)XLR-V	Powertrain	Transmission Control Module																																																											
Y	2007	(YX)XLR-V	Chassis	Electronic Brake Control Module																																																											
Y	2007	(YX)XLR-V	Chassis	Electronic Suspension Control																																																											
Y	2007	(YX)XLR-V	Body	Amplifier (Bose)																																																											
Y	2007	(YX)XLR-V	Body	Body Control Module																																																											
Y	2007	(YX)XLR-V	Body	CD Changer																																																											
Y	2007	(YX)XLR-V	Body	Digital Radio Receiver																																																											
Y	2007	(YX)XLR-V	Body	Distance Sensing Cruise Control																																																											
Y	2007	(YX)XLR-V	Body	Driver Door Module																																																											
Y	2007	(YX)XLR-V	Body	Driver Door Switch																																																											
Y	2007	(YX)XLR-V	Body	Driver Position Module																																																											
Y	2007	(YX)XLR-V	Body	Folding Top Module																																																											
Y	2007	(YX)XLR-V	Body	Headlamp Control Module																																																											
Y	2007	(YX)XLR-V	Body	Head Up Display																																																											
Y	2007	(YX)XLR-V	Body	HVAC Control Module																																																											
Y	2007	(YX)XLR-V	Body	Instrument Panel Cluster																																																											
Y	2007	(YX)XLR-V	Body	Navigation Radio																																																											
Y	2007	(YX)XLR-V	Body	Passenger Door Module																																																											
Y	2007	(YX)XLR-V	Body	Remote Control Door Lock Receiver																																																											
Y	2007	(YX)XLR-V	Body	Steering Column Lock Module																																																											
Y	2007	(YX)XLR-V	Body	Supplemental Inflatable Restraint																																																											
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																											
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																											
Y	2008	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																											
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																											
Y	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2008	ALL	Chassis	Electronic Suspension Control																																																											
Y	2008	ALL	Body	Amplifier (Bose)																																																											
Y	2008	ALL	Body	Body Control Module																																																											
Y	2008	ALL	Body	CD Changer																																																											
Y	2008	ALL	Body	Digital Radio Receiver																																																											
Y	2008	ALL	Body	Distance Sensing Cruise Control																																																											
Y	2008	ALL	Body	Driver Door Module																																																											
Y	2008	ALL	Body	Driver Door Switch																																																											
Y	2008	ALL	Body	Driver Position Module																																																											
Y	2008	ALL	Body	Folding Top Module																																																											
Y	2008	ALL	Body	Headlamp Control Module																																																											
Y	2008	ALL	Body	Head Up Display																																																											
Y	2008	ALL	Body	HVAC Control Module																																																											
Y	2008	ALL	Body	Instrument Panel Cluster																																																											
Y	2008	ALL	Body	Navigation Radio																																																											
Y	2008	ALL	Body	Passenger Door Module																																																											
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Y	2008	ALL	Body	Steering Column Lock Module																																																									
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Body	Vehicle Comm. Interface Module																																																										
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Engine Control Module																																																										
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Exhaust Flow Control Module																																																										
Y	2009	ALL	Powertrain	(D)4.4L V8 LC3 Transmission Control Module																																																										
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
Y	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
Y	2009	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2009	ALL	Chassis	Electronic Suspension Control																																																										
Y	2009	ALL	Body	Amplifier (Bose)																																																										
Y	2009	ALL	Body	Body Control Module																																																									
Y	2009	ALL	Body	CD Changer																																																									
Y	2009	ALL	Body	Digital Radio Receiver																																																									
Y	2009	ALL	Body	Distance Sensing Cruise Control																																																									
Y	2009	ALL	Body	Driver Door Module																																																									
Y	2009	ALL	Body	Driver Door Switch																																																									
Y	2009	ALL	Body	Driver Position Module																																																									
Y	2009	ALL	Body	Folding Top Module																																																									
Y	2009	ALL	Body	Headlamp Control Module																																																									
Y	2009	ALL	Body	Head Up Display																																																									
Y	2009	ALL	Body	HVAC Control Module																																																									
Y	2009	ALL	Body	Instrument Panel Cluster																																																									
Y	2009	ALL	Body	Navigation Radio																																																									
Y	2009	ALL	Body	Passenger Door Module																																																									
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2009	ALL	Body	Steering Column Lock Module																																																										
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
1	2013	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2013	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2013	XTS	Powertrain	Fuel Pump Control Module																																																										
1	2013	XTS	Powertrain	Rear Differential Clutch Control Module																																																										
1	2013	XTS	Chassis	Electronic Brake Control Module																																																										
1	2013	XTS	Chassis	Parking Brake Control Module																																																										
1	2013	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2013	XTS	Chassis	Power Steering Control Module																																																										
1	2013	XTS	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2013	XTS	Chassis	Suspension Control Module																																																										
1	2013	XTS	Body	Body Control Module																																																										
1	2013	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2013	XTS	Body	Passenger Presence Module																																																										
1	2013	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
1	2013	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
1	2013	XTS	Body	Radio/HVAC Control																																																										
1	2013	XTS	Body	Active Safety Control Module																																																										
1	2013	XTS	Body	Headlamp Control Module																																																										
1	2013	XTS	Body	Radio																																																										
1	2013	XTS	Body	Amplifier																																																										
1	2013	XTS	Body	Human Machine Interface Control Module																																																										
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2013	XTS	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2013	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2013	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
1	2013	XTS	Body	Seat Memory Control Module																																																										
1	2013	XTS	Body	Keyless Entry Control Module																																																										
1	2013	XTS	Body	Right Side Object Detection Control Module																																																										
1	2013	XTS	Body	Left Side Object Detection Control Module																																																										
1	2013	XTS	Body	Parking Assist Control Module																																																										
1	2013	XTS	Body	Frontview Camera Module																																																										
1	2013	XTS	Body	Long Range Radar Sensor Module																																																										
1	2013	XTS	Body	Left Front Short Range Radar Sensor Module																																																										
1	2013	XTS	Body	Right Front Short Range Radar Sensor Module																																																										
1	2013	XTS	Body	Rear Short Range Radar Sensor Module																																																										
1	2014	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																										
1	2014	XTS	Powertrain	(8) 3.6L LF3 Chassis Control Module																																																										
1	2014	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																										
1	2014	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2014	XTS	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
1	2014	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2014	XTS	Powertrain	Rear Differential Clutch Control Module																																																										
1	2014	XTS	Chassis	Electronic Brake Control Module																																																										
1	2014	XTS	Chassis	Parking Brake Control Module																																																										
1	2014	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2014	XTS	Chassis	Power Steering Control Module																																																										
1	2014	XTS	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2014	XTS	Chassis	Suspension Control Module																																																										
1	2014	XTS	Body	Body Control Module																																																										
1	2014	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	XTS	Body	Passenger Presence Module																																																										
1	2014	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
1	2014	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																										
1	2014	XTS	Body	Radio/HVAC Control																																																										
1	2014	XTS	Body	Active Safety Control Module																																																										
1	2014	XTS	Body	Headlamp Control Module																																																										
1	2014	XTS	Body	Radio																																																										
1	2014	XTS	Body	Amplifier																																																										
1	2014	XTS	Body	Media Disc Player																																																										
1	2014	XTS	Body	Human Machine Interface Control Module																																																										
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	XTS	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
1	2014	XTS	Body	Seat Memory Control Module - Passenger																																																										
1	2014	XTS	Body	Seat Memory Control Module - Driver																																																										
1	2014	XTS	Body	Keyless Entry Control Module																																																										
1	2014	XTS	Body	Right Side Object Detection Control Module																																																										
1	2014	XTS	Body	Left Side Object Detection Control Module																																																										
1	2014	XTS	Body	Parking Assist Control Module																																																										
1	2014	XTS	Body	Frontview Camera Module																																																										
1	2014	XTS	Body	Long Range Radar Sensor Module																																																										
1	2014	XTS	Body	Left Front Short Range Radar Sensor Module																																																										
1	2014	XTS	Body	Right Front Short Range Radar Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2014	XTS	Body	Rear Short Range Radar Sensor Module																																																								
1	2015	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																								
1	2015	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																								
1	2015	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
1	2015	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
1	2015	XTS	Powertrain	Chassis Control Module																																																								
1	2015	XTS	Powertrain	Rear Differential Clutch Control Module																																																								
1	2015	XTS	Chassis	Electronic Brake Control Module																																																								
1	2015	XTS	Chassis	Parking Brake Control Module																																																								
1	2015	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																								
1	2015	XTS	Chassis	Power Steering Control Module																																																								
1	2015	XTS	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2015	XTS	Chassis	Suspension Control Module																																																								
1	2015	XTS	Body	Body Control Module																																																								
1	2015	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2015	XTS	Body	Passenger Presence Module																																																								
1	2015	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																								
1	2015	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																								
1	2015	XTS	Body	Radio/HVAC Control																																																								
1	2015	XTS	Body	Active Safety Control Module																																																								
1	2015	XTS	Body	Radio																																																								
1	2015	XTS	Body	Amplifier																																																								
1	2015	XTS	Body	Media Disc Player																																																								
1	2015	XTS	Body	Human Machine Interface Control Module																																																								
1	2015	XTS	Body	Telematics Communication Interface Control Module																																																								
1	2015	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
1	2015	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																								
1	2015	XTS	Body	Seat Memory Control Module - Passenger																																																								
1	2015	XTS	Body	Seat Memory Control Module - Driver																																																								
1	2015	XTS	Body	Keyless Entry Control Module																																																								
1	2015	XTS	Body	Right Side Object Detection Control Module																																																								
1	2015	XTS	Body	Left Side Object Detection Control Module																																																								
1	2015	XTS	Body	Parking Assist Control Module GMLAN																																																								
1	2015	XTS	Body	Parking Assist Control Module DID72History																																																								
1	2015	XTS	Body	Frontview Camera Module																																																								
1	2015	XTS	Body	Long Range Radar Sensor Module																																																								
1	2015	XTS	Body	Left Front Short Range Radar Sensor Module																																																								
1	2015	XTS	Body	Right Front Short Range Radar Sensor Module																																																								
1	2015	XTS	Body	Rear Short Range Radar Sensor Module																																																								
1	2016	XTS	Powertrain	(8) 3.6L LF3 Engine Control Module																																																								
1	2016	XTS	Powertrain	(8) 3.6L LF3 Transmission Control Module																																																								
1	2016	XTS	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
1	2016	XTS	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
1	2016	XTS	Powertrain	Chassis Control Module																																																								
1	2016	XTS	Powertrain	Rear Differential Clutch Control Module																																																								
1	2016	XTS	Chassis	Electronic Brake Control Module																																																								
1	2016	XTS	Chassis	Parking Brake Control Module																																																								
1	2016	XTS	Chassis	Multi-Axis Acceleration Sensor Module																																																								
1	2016	XTS	Chassis	Power Steering Control Module																																																								
1	2016	XTS	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2016	XTS	Chassis	Suspension Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2016	XTS	Body	Body Control Module																																																												
1	2016	XTS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
1	2016	XTS	Body	Passenger Presence Module																																																													
1	2016	XTS	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																													
1	2016	XTS	Body	Instrument Cluster Full Screen Display (UDV)																																																													
1	2016	XTS	Body	Radio/HVAC Control																																																													
1	2016	XTS	Body	Active Safety Control Module																																																													
1	2016	XTS	Body	Video Processing Control Module																																																													
1	2016	XTS	Body	Radio																																																													
1	2016	XTS	Body	Amplifier																																																													
1	2016	XTS	Body	Media Disc Player																																																													
1	2016	XTS	Body	Human Machine Interface Control Module																																																													
1	2016	XTS	Body	Telematics Communication Interface Control Module																																																													
1	2016	XTS	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
1	2016	XTS	Body	HVAC Auto Control Tri Zone (CJ4)																																																													
1	2016	XTS	Body	Seat Memory Control Module - Passenger																																																													
1	2016	XTS	Body	Seat Memory Control Module - Driver																																																													
1	2016	XTS	Body	Keyless Entry Control Module																																																													
1	2016	XTS	Body	Right Side Object Detection Control Module																																																													
1	2016	XTS	Body	Left Side Object Detection Control Module																																																													
1	2016	XTS	Body	Parking Assist Control Module																																																													
1	2016	XTS	Body	Frontview Camera Module																																																													
1	2016	XTS	Body	Steering Column Lock Control Module																																																													
1	2016	XTS	Body	Long Range Radar Sensor Module																																																													
1	2016	XTS	Body	Left Front Short Range Radar Sensor Module																																																													
1	2016	XTS	Body	Right Front Short Range Radar Sensor Module																																																													
1	2016	XTS	Body	Rear Short Range Radar Sensor Module																																																													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2005	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module	V	V	V						V			V	V	V			V	V		V								V													V														
A	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
A	2005	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V																								
A	2005	ALL	Chassis	Power Steering Control Module	V	V																																																				
A	2005	ALL	Chassis	Anti-lock Brake System	V	V																		V	V																																	
A	2005	ALL	Body	Body Control Module	V	V																		V	V																																	
A	2005	ALL	Body	Digital Radio Receiver	V	V																																																			
A	2005	ALL	Body	Instrument Panel	V	V																		V	V																																	
A	2005	ALL	Body	Radio	V	V																		V	V																																	
A	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																	
A	2006	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module	V	V	V						V			V	V	V			V	V		V								V													V														
A	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
A	2006	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
A	2006	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V																								
A	2006	ALL	Chassis	Power Steering Control Module	V	V																																																				
A	2006	ALL	Chassis	Anti-lock Brake System	V	V																		V	V																																	
A	2006	ALL	Body	Body Control Module	V	V																		V	V																																	
A	2006	ALL	Body	Digital Radio Receiver	V	V																																																			
A	2006	ALL	Body	Instrument Panel	V	V																		V	V																																	
A	2006	ALL	Body	Radio	V	V																		V	V																																	
A	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																	
A	2006	ALL	Body	Theft Deterrent Module	V	V																			V																																	
A	2007	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module	V	V	V						V			V	V	V			V	V		V								V													V														
A	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
A	2007	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
A	2007	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V																								
A	2007	ALL	Chassis	Power Steering Control Module	V	V																																																				
A	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																	
A	2007	ALL	Body	Body Control Module	V	V																		V	V																																	
A	2007	ALL	Body	Digital Radio Receiver	V	V																																																			
A	2007	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																	
A	2007	ALL	Body	Passenger Presence System	V																																																				
A	2007	ALL	Body	Personal Audio Link Module	V																			V	V																																	
A	2007	ALL	Body	Radio	V	V																		V	V																																	
A	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																	
A	2007	ALL	Body	Theft Deterrent Module	V	V																			V																																	
A	2008	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																																	
A	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
A	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
A	2008	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V																								
A	2008	ALL	Chassis	Power Steering Control Module	V	V																																																				
A	2008	ALL	Chassis	Electronic Brake Control Module with VSES	V	V																		V	V																																	
A	2008	ALL	Chassis	Electronic Brake Control Module without VSES	V	V																		V	V																																	
A	2008	ALL	Body	Body Control Module	V	V																		V	V																																	
A	2008	ALL	Body	Digital Radio Receiver	V	V																			V																																	
A	2008	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																	
A	2008	ALL	Body	Passenger Presence System	V																																																				
A	2008	ALL	Body	Personal Audio Link Module	V																			V	V																																	
A	2008	ALL	Body	Radio	V	V																		V	V																																	
A	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																	
A	2008	ALL	Body	Theft Deterrent Module	V	V																			V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2009	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																																				
A	2009	ALL	Powertrain	(H)2.2L L4 LAP Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
A	2009	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V																									
A	2009	ALL	Chassis	Power Steering Control Module	V	V																																																						
A	2009	ALL	Chassis	Electronic Brake Control Module with VSES	V	V																		V	V																																			
A	2009	ALL	Chassis	Electronic Brake Control Module without VSES	V	V																		V	V																																			
A	2009	ALL	Body	Body Control Module	V	V																		V	V																																			
A	2009	ALL	Body	Digital Radio Receiver	V	V																		V																																				
A	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
A	2009	ALL	Body	Passenger Presence System	V																																																						
A	2009	ALL	Body	Personal Audio Link Module	V																			V	V																																			
A	2009	ALL	Body	Radio	V	V																		V	V																																			
A	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
A	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																			
A	2010	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																																			
A	2010	ALL	Powertrain	(5)2.2L L4 LAP Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
A	2010	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V																									
A	2010	ALL	Chassis	Power Steering Control Module	V	V																																																						
A	2010	ALL	Chassis	Electronic Brake Control Module with VSES	V	V																		V	V																																			
A	2010	ALL	Chassis	Electronic Brake Control Module without VSES	V	V																		V	V																																			
A	2010	ALL	Body	Body Control Module	V	V																		V	V																																			
A	2010	ALL	Body	Digital Radio Receiver	V	V																		V																																				
A	2010	ALL	Body	Driver Information Center	V	V																		V	V																																			
A	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
A	2010	ALL	Body	Passenger Presence System	V																																																						
A	2010	ALL	Body	Personal Audio Link Module	V																			V	V																																			
A	2010	ALL	Body	Radio	V	V																		V	V																																			
A	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
A	2010	ALL	Body	Theft Deterrent Module	V	V																			V																																			
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
A	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																			
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																			
A	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
A	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2012	Cobalt	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V					
A	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
A	2012	Cobalt	Chassis	Electric Power Steering Control Module	V	V																			V																																			
A	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
A	2012	Cobalt	Body	Body Control Module	V	V																		V	V																																			
A	2012	Cobalt	Body	Passenger Presence Module	V	V																			V																																			
A	2012	Cobalt	Body	Instrument Cluster	V	V																		V	V																																			
A	2012	Cobalt	Body	Radio	V	V																		V	V																																			
A	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module	V	V																		V	V																																			
A	2012	Cobalt	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
A	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
A	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
A	2012	Cobalt	Body	Front Seat Heating Control Module	V	V																		V	V																																			
A	2012	Cobalt	Body	Parking Assist Control Module	V	V																			V																																			
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V															
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V															
A	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V															
A	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V															
A	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
A	2013	Cobalt	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V								
A	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
A	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
A	2013	Cobalt	Body	Body Control Module	V	V																		V	V																																			
A	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
A	2013	Cobalt	Body	Instrument Cluster	V	V																		V	V																																			
A	2013	Cobalt	Body	Radio	V	V																		V	V																																			
A	2013	Cobalt	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
A	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																			
A	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
A	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
A	2013	Cobalt	Body	Front Seat Heating Control Module	V	V																		V	V																																			
A	2013	Cobalt	Body	Parking Assist Control Module	V	V																		V	V																																			
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V															
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V															
A	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V															
A	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V															
A	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
A	2014	Cobalt	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V								
A	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
A	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
A	2014	Cobalt	Body	Body Control Module	V	V																		V	V																																			
A	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
A	2014	Cobalt	Body	Instrument Cluster	V	V																		V	V																																			
A	2014	Cobalt	Body	Radio	V	V																		V	V																																			
A	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																				
A	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
A	2014	Cobalt	Body	Front Seat Heating Control Module	V	V																		V	V																																			
A	2014	Cobalt	Body	Parking Assist Control Module	V	V																		V	V																																			
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
A	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
A	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
A	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
A	2015	Cobalt	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V							
A	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
A	2015	Cobalt	Body	Body Control Module	V	V																		V	V																																			
A	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
A	2015	Cobalt	Body	Instrument Cluster	V	V																		V	V																																			
A	2015	Cobalt	Body	Radio	V	V																		V	V																																			
A	2015	Cobalt	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
A	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																			
A	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
A	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
A	2015	Cobalt	Body	Front Seat Heating Control Module	V	V																		V	V																																			
A	2015	Cobalt	Body	Parking Assist Control Module	V	V																			V																																			
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
A	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
A	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
A	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
A	2016	Cobalt	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V							
A	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
A	2016	Cobalt	Body	Body Control Module	V	V																		V	V																																			
A	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module	V																																																						
A	2016	Cobalt	Body	Instrument Cluster	V	V																		V	V																																			
A	2016	Cobalt	Body	Radio Other	V	V																		V	V																																			
A	2016	Cobalt	Body	Radio (IOB)	V	V																		V	V																																			
A	2016	Cobalt	Body	Radio (UF7)	V	V																		V	V																																			
A	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
A	2016	Cobalt	Body	Front Seat Heating Control Module	V	V																		V	V																																			
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission	V																			V	V					V																														
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission	V																			V	V					V																														
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
B	2010	Beat	Powertrain	Transmission Control Module	V	V																		V	V																																			
B	2010	Beat	Chassis	Electronic Brake Control Module	V	V																			V													V										V												
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
B	2010	Beat	Chassis	Power Steering Control Module	V	V																			V																																			
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
B	2010	Beat	Body	Instrument Cluster	V	V																		V	V																																			
B	2010	Beat	Body	Keyless Entry Control Module		V																																																						
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission	V																			V	V					V																														
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission	V																			V	V					V																														
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
B	2011	Beat	Powertrain	Transmission Control Module	V	V																		V	V																																			
B	2011	Beat	Chassis	Electronic Brake Control Module	V	V																			V													V										V												
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
B	2011	Beat	Chassis	Electric Power Steering Control Module	V	V																			V																																			
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
B	2011	Beat	Body	Instrument Cluster	V	V																		V	V																																			
B	2011	Beat	Body	Keyless Entry Control Module		V																																																						
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module	V																			V	V					V																														
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
B	2012	Beat	Powertrain	Transmission Control Module	V	V																		V	V																																			
B	2012	Beat	Chassis	Electronic Brake Control Module	V	V																			V													V										V												
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
B	2012	Beat	Chassis	Electric Power Steering Control Module	V	V																			V																																			
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
B	2012	Beat	Body	Instrument Cluster	V	V																		V	V																																			
B	2012	Beat	Body	Keyless Entry Control Module		V																																																						
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module	V																			V	V					V																														
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
B	2013	Beat	Powertrain	Transmission Control Module	V	V																		V	V																																			
B	2013	Beat	Chassis	Electronic Brake Control Module	V	V																			V													V										V												
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
B	2013	Beat	Chassis	Electric Power Steering Control Module	V	V																			V																																			
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
B	2013	Beat	Body	Instrument Cluster	V	V																		V	V																																			
B	2013	Beat	Body	Keyless Entry Control Module		V																																																						
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module	V																			V	V					V																														
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
B	2014	Beat	Powertrain	Transmission Control Module	V	V																		V	V																																			
B	2014	Beat	Powertrain	Fuel Injector Control Module	V	V																		V	V																																			
B	2014	Beat	Chassis	Electronic Brake Control Module	V	V																			V													V										V												
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
B	2014	Beat	Chassis	Power Steering Control Module	V	V																			V																																					
B	2014	Beat	Chassis	Steering Wheel Angle Sensor Module	V																				V																																					
B	2014	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																					
B	2014	Beat	Body	Instrument Cluster	V	V																		V	V																																					
B	2014	Beat	Body	Telematics Communication Interface Control Module	V	V																		V	V																																					
B	2015	Beat	Powertrain	1.0L LEB Engine Control Module	V																			V	V						V																															
B	2015	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																				
B	2015	Beat	Powertrain	Transmission Control Module	V	V																		V	V																																					
B	2015	Beat	Powertrain	Fuel Injector Control Module		V																		V	V																																					
B	2015	Beat	Chassis	Electronic Brake Control Module	V	V																			V													V										V													
B	2015	Beat	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			V	V
B	2015	Beat	Chassis	Power Steering Control Module	V	V																			V																																					
B	2015	Beat	Chassis	Steering Wheel Angle Sensor Module	V																				V																																					
B	2015	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																					
B	2015	Beat	Body	Instrument Cluster	V	V																		V	V																																					
B	2015	Beat	Body	Radio	V	V																		V	V																																					
B	2015	Beat	Body	Telematics Communication Interface Control Module	V	V																		V	V																																					
B	2015	Beat	Body	Keyless Entry Control Module		V																																																								
B	2016	Beat	Powertrain	1.0L LEB Engine Control Module	V																			V	V																																					
B	2016	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																				
B	2016	Beat	Powertrain	Transmission Control Module	V	V																		V	V																																					
B	2016	Beat	Chassis	Electronic Brake Control Module	V	V																			V													V										V													
B	2016	Beat	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			V	V
B	2016	Beat	Chassis	Power Steering Control Module	V	V																			V																																					
B	2016	Beat	Chassis	Steering Wheel Angle Sensor Module	V																				V																																					
B	2016	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																					
B	2016	Beat	Body	Instrument Cluster	V	V																		V	V																																					
B	2016	Beat	Body	Radio	V	V																		V	V																																					
B	2016	Beat	Body	Telematics Communication Interface Control Module	V	V																		V	V																																					
B	2016	Beat	Body	HVAC Control Module	V	V																		V	V																																					
B	2016	Beat	Body	Keyless Entry Control Module		V																																																							
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V															
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V													V	V														
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V															
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V													V	V														
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V														V														
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V													V	V														
B	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V															
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V													V	V														
B	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
B	2016	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V				V		
B	2016	Cruze	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																					
B	2016	Cruze	Chassis	Power Steering Control Module	V	V																			V																																					
B	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																					
B	2016	Cruze	Body	Body Control Module	V	V																		V	V																																					
B	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																					
B	2016	Cruze	Body	Passenger Presence Module	V	V																			V																																					
B	2016	Cruze	Body	Instrument Cluster	V	V																		V	V																																					
B	2016	Cruze	Body	Radio Controls	V																				V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
B	2016	Cruze	Body	HVAC Controls	V																			V	V																																			
B	2016	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																			
B	2016	Cruze	Body	Radio Base (IO3 IO7)	V	V																		V	V																																			
B	2016	Cruze	Body	Radio (IOA)	V	V																		V	V																																			
B	2016	Cruze	Body	Radio (IOB)	V	V																		V	V																																			
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)	V	V																		V	V																																			
B	2016	Cruze	Body	Amplifier	V	V																			V																																			
B	2016	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																			
B	2016	Cruze	Body	Human Machine Interface Control Module	V	V																		V	V																							V												
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)	V	V																		V	V																																			
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																			
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
B	2016	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																			
B	2016	Cruze	Body	Right Side Object Detection Control Module	V																			V	V																																			
B	2016	Cruze	Body	Left Side Object Detection Control Module	V																			V	V																																			
B	2016	Cruze	Body	Parking Assist Control Module	V																			V	V																																			
B	2016	Cruze	Body	Frontview Camera Module	V	V																		V	V																																			
B	2016	Cruze	Body	Steering Column Lock Control Module	V	V																			V																																			
B	2016	Cruze	Body	Long Range Radar Sensor Module	V	V																			V																																			
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module	V	V																		V	V																																			
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module	V																			V	V																																			
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module	V																			V	V																																			
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2010	Spark	Powertrain	Transmission Control Module	V	V																		V	V																																			
C	2010	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V											V												
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
C	2010	Spark	Chassis	Electric Power Steering Control Module	V	V																			V																																			
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
C	2010	Spark	Body	Passenger Presence Module	V	V																			V																																			
C	2010	Spark	Body	Instrument Cluster	V	V																		V	V																																			
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module	V	V																		V	V																																			
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module	V																			V	V																																			
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module	V																			V	V																																			
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2011	Spark	Powertrain	Transmission Control Module	V	V																		V	V																																			
C	2011	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V											V												
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
C	2011	Spark	Chassis	Electric Power Steering Control Module	V	V																			V																																			
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
C	2011	Spark	Body	Passenger Presence Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2011	Spark	Body	Instrument Cluster	V	V																		V	V																																				
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module	V	V																		V	V																																			
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module	V																			V	V																																			
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module	V																			V	V																																			
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2012	Spark	Powertrain	Transmission Control Module	V	V																		V	V																																			
C	2012	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V										V												
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
C	2012	Spark	Chassis	Electric Power Steering Control Module	V	V																			V																																			
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
C	2012	Spark	Body	Passenger Presence Module	V	V																			V																																			
C	2012	Spark	Body	Instrument Cluster	V	V																		V	V																																			
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module	V	V																		V	V																																			
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module	V	V																		V	V																																			
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module	V	V																		V	V																																			
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																												
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V																												
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module	V	V																		V	V										V	V	V	V																						
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module	V	V																		V	V																																			
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module	V																			V	V																																			
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																			
C	2013	Spark	Powertrain	Fuel Injector Control Module	V	V																		V	V																																			
C	2013	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V										V												
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
C	2013	Spark	Chassis	Power Steering Control Module	V	V																			V																																			
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2013	Spark	Body	Body Control Module	V	V																		V	V																																			
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
C	2013	Spark	Body	Passenger Presence Module	V	V																			V																																			
C	2013	Spark	Body	Instrument Cluster	V	V																		V	V																																			
C	2013	Spark	Body	Radio	V	V																		V	V																																			
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module	V	V																		V	V																																			
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module	V	V																		V	V																																			
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																													
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V																
C	2014	Spark	Powertrain	1.0L LFM Transmission Control Module	V	V																		V	V									V	V	V	V																							
C	2014	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
C	2014	Spark	Powertrain	1.0L LMT Transmission Control Module	V	V																		V	V																																		
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																		
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V															
C	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module	V	V																		V	V									V	V	V	V																						
C	2014	Spark	Powertrain	1.2L LKY Engine Control Module	V																			V	V																																		
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																		
C	2014	Spark	Powertrain	Fuel Injector Control Module		V																		V	V																																		
C	2014	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V										V											
C	2014	Spark	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					
C	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
C	2014	Spark	Chassis	Power Steering Control Module	V	V																			V																																	
C	2014	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
C	2014	Spark	Body	Body Control Module	V	V																		V	V																																	
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																	
C	2014	Spark	Body	Passenger Presence Module	V	V																			V																																	
C	2014	Spark	Body	Instrument Cluster	V	V																		V	V																																	
C	2014	Spark	Body	Radio	V	V																		V	V																																	
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
C	2014	Spark	Body	Keyless Entry Control Module		V																																																				
C	2014	Spark EV	Powertrain	Engine Control Module	V																			V	V								V																											
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module	V	V																		V	V										V																							
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V	V																		V	V																																	
C	2014	Spark EV	Powertrain	Drive Motor Control Module		V																			V																																	
C	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																	
C	2014	Spark EV	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					
C	2014	Spark EV	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
C	2014	Spark EV	Chassis	Power Steering Control Module	V	V																			V																																	
C	2014	Spark EV	Body	Body Control Module	V	V																		V	V																																	
C	2014	Spark EV	Body	Pedestrian Alert Sound Control Module	V	V																			V																																	
C	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
C	2014	Spark EV	Body	Passenger Presence Module	V	V																			V																																	
C	2014	Spark EV	Body	Instrument Cluster	V	V																		V	V																																	
C	2014	Spark EV	Body	Radio	V	V																		V	V																																	
C	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
C	2014	Spark EV	Body	HVAC Control Module	V	V																		V	V																																	
C	2014	Spark EV	Body	Electric A/C Compressor Control Module																					V																																	
C	2014	Spark EV	Body	Coolant Heater Control Module	V																				V																																	
C	2014	Spark EV	Body	Keyless Entry Control Module	V	V																			V																																	
C	2014	Spark EV	Body	Battery Charger Control Module		V																			V																																	
C	2014	Spark EV	Body	DC Charging Control Module		V																			V																																	
C	2014	Spark EV	Body	Battery Energy Control Module		V																			V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2015	Spark	Powertrain	0.8L LBF Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
C	2015	Spark	Powertrain	0.8L LBF Transmission Control Module	V	V																		V	V																																		
C	2015	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V	V			V			V			V	V					V		V	V																																		
C	2015	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
C	2015	Spark	Powertrain	1.0L LCP Transmission Control Module	V	V																		V	V																																		
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V														
C	2015	Spark	Powertrain	1.0L LFM Transmission Control Module	V	V																		V	V										V	V	V	V																				
C	2015	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
C	2015	Spark	Powertrain	1.0L LMT Transmission Control Module	V	V																		V	V																																		
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																		
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V														
C	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module	V	V																		V	V										V	V	V	V																				
C	2015	Spark	Powertrain	1.2L LKY Engine Control Module	V																			V	V																																		
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																		
C	2015	Spark	Powertrain	Fuel Injector Control Module		V																		V	V																																		
C	2015	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V									V												
C	2015	Spark	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					
C	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
C	2015	Spark	Chassis	Power Steering Control Module	V	V																			V																																	
C	2015	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
C	2015	Spark	Body	Body Control Module	V	V																		V	V																																	
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																	
C	2015	Spark	Body	Passenger Presence Module	V	V																			V																																	
C	2015	Spark	Body	Instrument Cluster	V	V																		V	V																																	
C	2015	Spark	Body	Instrument Cluster	V	V																		V	V																																	
C	2015	Spark	Body	Tire Pressure Indicator Module	V	V																			V																																	
C	2015	Spark	Body	Radio	V	V																		V	V																																	
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
C	2015	Spark	Body	Keyless Entry Control Module		V																			V																																	
C	2015	Spark EV	Powertrain	Engine Control Module	V																			V	V								V																											
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module	V	V																		V	V										V																								
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V	V																		V	V																																	
C	2015	Spark EV	Powertrain	Drive Motor Control Module		V																			V																																	
C	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																	
C	2015	Spark EV	Chassis	Electronic Brake Control Module	V	V																		V	V																													V					
C	2015	Spark EV	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
C	2015	Spark EV	Chassis	Power Steering Control Module	V	V																			V																																	
C	2015	Spark EV	Body	Body Control Module	V	V																		V	V																																	
C	2015	Spark EV	Body	Pedestrian Alert Sound Control Module	V	V																			V																																	
C	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
C	2015	Spark EV	Body	Passenger Presence Module	V	V																			V																																	
C	2015	Spark EV	Body	Instrument Cluster	V	V																		V	V																																	
C	2015	Spark EV	Body	Radio	V	V																		V	V																																	
C	2015	Spark EV	Body	HVAC Control Module	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2015	Spark EV	Body	Electric A/C Compressor Control Module																					V																																			
C	2015	Spark EV	Body	Coolant Heater Control Module	V																				V																																			
C	2015	Spark EV	Body	Keyless Entry Control Module	V	V																			V																																			
C	2015	Spark EV	Body	Battery Charger Control Module		V																			V																																			
C	2015	Spark EV	Body	DC Charging Control Module		V																			V																																			
C	2015	Spark EV	Body	Battery Energy Control Module		V																			V																																			
C	2016	Spark	Powertrain	0.8L LBF Engine Control Module	V	V	V			V			V			V	V					V		V	V																																		
C	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module	V	V																		V	V																																		
C	2016	Spark	Powertrain	0.8L LBF Transmission Control Module	V	V																		V	V																																		
C	2016	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V	V			V			V			V	V					V		V	V																																		
C	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module	V	V																		V	V																																		
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V	V																										
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V	V											V														
C	2016	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
C	2016	Spark	Powertrain	1.0L LCP Transmission Control Module	V	V																		V	V																																		
C	2016	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
C	2016	Spark	Powertrain	1.0L LMT Transmission Control Module	V	V																		V	V																																		
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
C	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module	V	V																		V	V																																		
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																		
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																										
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V														
C	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module	V	V																		V	V										V	V	V	V																				
C	2016	Spark	Powertrain	1.2L LKY Engine Control Module	V																			V	V																																		
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																		
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V	V																										
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V	V											V														
C	2016	Spark	Powertrain	Fuel Injector Control Module		V																		V	V																																		
C	2016	Spark	Chassis	Electronic Brake Control Module	V	V																			V													V										V											
C	2016	Spark	Chassis	Electronic Brake Control Module	V	V																		V	V																												V						
C	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
C	2016	Spark	Chassis	Power Steering Control Module	V	V																			V																																			
C	2016	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2016	Spark	Body	Body Control Module	V	V																		V	V																																		
C	2016	Spark	Body	Body Control Module	V	V																		V	V																																		
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																		
C	2016	Spark	Body	Instrument Cluster	V	V																		V	V																																		
C	2016	Spark	Body	Instrument Cluster	V	V																		V	V																																		
C	2016	Spark	Body	Radio	V	V																		V	V																																		
C	2016	Spark	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
C	2016	Spark	Body	Keyless Entry Control Module		V																																																					
C	2016	Spark EV	Powertrain	Engine Control Module	V																			V	V							V																												
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module	V	V																		V	V									V																									
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V	V																		V	V																																		
C	2016	Spark EV	Powertrain	Drive Motor Control Module		V																			V																																		
C	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																		
C	2016	Spark EV	Chassis	Electronic Brake Control Module	V	V																		V	V																													V					
C	2016	Spark EV	Chassis	Parking Brake Control Module	V	V																			V																														V	V	V	V		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2016	Spark EV	Chassis	Power Steering Control Module	V	V																			V																																					
C	2016	Spark EV	Body	Body Control Module	V	V																		V	V																																					
C	2016	Spark EV	Body	Pedestrian Alert Sound Control Module	V	V																			V																																					
C	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																					
C	2016	Spark EV	Body	Passenger Presence Module	V	V																			V																																					
C	2016	Spark EV	Body	Instrument Cluster	V	V																		V	V																																					
C	2016	Spark EV	Body	Radio	V	V																		V	V																																					
C	2016	Spark EV	Body	Telematics Communication Interface Control Module	V	V																		V	V																																					
C	2016	Spark EV	Body	HVAC Control Module	V	V																		V	V																																					
C	2016	Spark EV	Body	Electric A/C Compressor Control Module																					V																																					
C	2016	Spark EV	Body	Coolant Heater Control Module	V																				V																																					
C	2016	Spark EV	Body	Keyless Entry Control Module	V	V																			V																																					
C	2016	Spark EV	Body	Frontview Camera Module	V	V																		V	V																																					
C	2016	Spark EV	Body	Battery Charger Control Module		V																			V																																					
C	2016	Spark EV	Body	DC Charging Control Module		V																			V																																					
C	2016	Spark EV	Body	Battery Energy Control Module		V																			V																																					
D	2010	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																					
D	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module	V	V																		V	V																																					
D	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module	V																			V	V																																					
D	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module	V																			V	V																																					
D	2010	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																					
D	2010	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																					
D	2010	Spark	Powertrain	Transmission Control Module	V	V																		V	V																																					
D	2010	Spark	Chassis	Electronic Brake Control Module	V	V																			V													V										V													
D	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			V	V
D	2010	Spark	Chassis	Electric Power Steering Control Module	V	V																			V																																					
D	2010	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																					
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																					
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																					
D	2010	Spark	Body	Passenger Presence Module	V	V																			V																																					
D	2010	Spark	Body	Instrument Cluster	V	V																		V	V																																					
D	2011	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																					
D	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module	V	V																		V	V																																					
D	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module	V																			V	V																																					
D	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module	V																			V	V																																					
D	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																					
D	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																					
D	2011	Spark	Powertrain	Transmission Control Module	V	V																		V	V																																					
D	2011	Spark	Chassis	Electronic Brake Control Module	V	V																			V													V										V													
D	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			V	V
D	2011	Spark	Chassis	Electric Power Steering Control Module	V	V																			V																																					
D	2011	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																					
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																					
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																					
D	2011	Spark	Body	Passenger Presence Module	V	V																			V																																					
D	2011	Spark	Body	Instrument Cluster	V	V																		V	V																																					
D	2012	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																					
D	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module	V	V																		V	V																																					
D	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module	V																			V	V																																					
D	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module	V																			V	V																																					
D	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2012	Spark	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																				
D	2012	Spark	Powertrain	1.2L L2E Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																				
D	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																				
D	2012	Spark	Powertrain	Transmission Control Module	V	V																		V	V																																				
D	2012	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V										V													
D	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
D	2012	Spark	Chassis	Electric Power Steering Control Module	V	V																			V																																			
D	2012	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
D	2012	Spark	Body	Passenger Presence Module	V	V																			V																																			
D	2012	Spark	Body	Instrument Cluster	V	V																		V	V																																			
D	2013	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
D	2013	Spark	Powertrain	1.0L LCP Transmission Control Module	V	V																		V	V																																			
D	2013	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
D	2013	Spark	Powertrain	1.0L LMT Transmission Control Module	V	V																		V	V																																			
D	2013	Spark	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
D	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module	V	V																		V	V																																			
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																												
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V																												
D	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module	V	V																		V	V										V	V	V	V																						
D	2013	Spark	Powertrain	1.2L L2E Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
D	2013	Spark	Powertrain	1.2L L2E Transmission Control Module	V	V																		V	V																																			
D	2013	Spark	Powertrain	1.2L LKY Engine Control Module	V																			V	V																																			
D	2013	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
D	2013	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																			
D	2013	Spark	Powertrain	Fuel Injector Control Module	V	V																		V	V																																			
D	2013	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V										V													
D	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
D	2013	Spark	Chassis	Power Steering Control Module	V	V																			V																																			
D	2013	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
D	2013	Spark	Body	Body Control Module	V	V																		V	V																																			
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
D	2013	Spark	Body	Passenger Presence Module	V	V																			V																																			
D	2013	Spark	Body	Instrument Cluster	V	V																		V	V																																			
D	2013	Spark	Body	Radio	V	V																		V	V																																			
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
D	2014	Spark	Powertrain	0.8L LBF Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
D	2014	Spark	Powertrain	0.8L LBF Transmission Control Module	V	V																		V	V																																			
D	2014	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
D	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module	V	V																		V	V																																			
D	2014	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
D	2014	Spark	Powertrain	1.0L LCP Transmission Control Module	V	V																		V	V																																			
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																												
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V															
D	2014	Spark	Powertrain	1.0L LFM Transmission Control Module	V	V																		V	V										V	V	V	V																						
D	2014	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
D	2014	Spark	Powertrain	1.0L LMT Transmission Control Module	V	V																		V	V																																			
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																			
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V															
D	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module	V	V																		V	V										V	V	V	V																					
D	2014	Spark	Powertrain	1.2L LKY Engine Control Module	V																			V	V																																	
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																	
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																	
D	2014	Spark	Powertrain	Fuel Injector Control Module		V																		V	V																																	
D	2014	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V									V												
D	2014	Spark	Chassis	Electronic Brake Control Module	V	V																		V	V																											V						
D	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																															V	V
D	2014	Spark	Chassis	Power Steering Control Module	V	V																			V																																
D	2014	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																
D	2014	Spark	Body	Body Control Module	V	V																		V	V																																
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																
D	2014	Spark	Body	Passenger Presence Module	V	V																			V																																
D	2014	Spark	Body	Instrument Cluster	V	V																		V	V																																
D	2014	Spark	Body	Radio	V	V																		V	V																																
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																
D	2014	Spark	Body	Keyless Entry Control Module		V																																																			
D	2014	Spark EV	Powertrain	Engine Control Module	V																			V	V								V																										
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module	V	V																		V	V										V																							
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V	V																		V	V																																
D	2014	Spark EV	Powertrain	Drive Motor Control Module		V																			V																																
D	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																
D	2014	Spark EV	Chassis	Electronic Brake Control Module	V	V																		V	V																												V				
D	2014	Spark EV	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
D	2014	Spark EV	Chassis	Power Steering Control Module	V	V																			V																																
D	2014	Spark EV	Body	Body Control Module	V	V																		V	V																																
D	2014	Spark EV	Body	Pedestrian Alert Sound Control Module	V	V																			V																																
D	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																
D	2014	Spark EV	Body	Passenger Presence Module	V	V																			V																																
D	2014	Spark EV	Body	Instrument Cluster	V	V																		V	V																																
D	2014	Spark EV	Body	Radio	V	V																		V	V																																
D	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																
D	2014	Spark EV	Body	HVAC Control Module	V	V																		V	V																																
D	2014	Spark EV	Body	Electric A/C Compressor Control Module																					V																																
D	2014	Spark EV	Body	Coolant Heater Control Module	V																				V																																
D	2014	Spark EV	Body	Keyless Entry Control Module	V	V																			V																																
D	2014	Spark EV	Body	Battery Charger Control Module		V																			V																																
D	2014	Spark EV	Body	DC Charging Control Module		V																			V																																
D	2014	Spark EV	Body	Battery Energy Control Module		V																			V																																
D	2015	Spark	Powertrain	0.8L LBF Engine Control Module	V	V	V			V			V			V	V					V		V	V																																
D	2015	Spark	Powertrain	0.8L LBF Transmission Control Module	V	V																		V	V																																
D	2015	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V	V			V			V			V	V					V		V	V																																
D	2015	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																
D	2015	Spark	Powertrain	1.0L LCP Transmission Control Module	V	V																		V	V																																
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																										

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V													V															
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module	V	V																		V	V										V	V	V	V																					
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																	
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module	V	V																		V	V																																	
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																	
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																	
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																										
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V														
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module	V	V																		V	V										V	V	V	V																					
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module	V																			V	V																																	
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																	
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																	
D	2015	Spark	Powertrain	Fuel Injector Control Module		V																		V	V																																	
D	2015	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V										V											
D	2015	Spark	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
D	2015	Spark	Chassis	Power Steering Control Module	V	V																			V																																	
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
D	2015	Spark	Body	Body Control Module	V	V																		V	V																																	
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																	
D	2015	Spark	Body	Passenger Presence Module	V	V																			V																																	
D	2015	Spark	Body	Instrument Cluster	V	V																		V	V																																	
D	2015	Spark	Body	Instrument Cluster	V	V																		V	V																																	
D	2015	Spark	Body	Tire Pressure Indicator Module	V	V																			V																																	
D	2015	Spark	Body	Radio	V	V																		V	V																																	
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
D	2015	Spark	Body	Keyless Entry Control Module		V																																																				
D	2015	Spark EV	Powertrain	Engine Control Module	V																			V	V								V																											
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module	V	V																		V	V										V																								
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V	V																		V	V																																	
D	2015	Spark EV	Powertrain	Drive Motor Control Module		V																			V																																	
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																	
D	2015	Spark EV	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					
D	2015	Spark EV	Chassis	Parking Brake Control Module	V	V																			V																						V						V	V	V	V		
D	2015	Spark EV	Chassis	Power Steering Control Module	V	V																			V																																	
D	2015	Spark EV	Body	Body Control Module	V	V																		V	V																																	
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module	V	V																			V																																	
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
D	2015	Spark EV	Body	Passenger Presence Module	V	V																			V																																	
D	2015	Spark EV	Body	Instrument Cluster	V	V																		V	V																																	
D	2015	Spark EV	Body	Radio	V	V																		V	V																																	
D	2015	Spark EV	Body	HVAC Control Module	V	V																		V	V																																	
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																					V																																	
D	2015	Spark EV	Body	Coolant Heater Control Module	V																				V																																	
D	2015	Spark EV	Body	Keyless Entry Control Module	V	V																			V																																	
D	2015	Spark EV	Body	Battery Charger Control Module		V																			V																																	
D	2015	Spark EV	Body	DC Charging Control Module		V																			V																																	
D	2015	Spark EV	Body	Battery Energy Control Module		V																			V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2016	Spark	Powertrain	0.8L LBF Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
D	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module	V	V																		V	V																																			
D	2016	Spark	Powertrain	0.8L LBF Transmission Control Module	V	V																		V	V																																			
D	2016	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
D	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module	V	V																		V	V																																			
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V														
D	2016	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
D	2016	Spark	Powertrain	1.0L LCP Transmission Control Module	V	V																		V	V																																		
D	2016	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
D	2016	Spark	Powertrain	1.0L LMT Transmission Control Module	V	V																		V	V																																		
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
D	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module	V	V																		V	V																																		
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																		
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V														
D	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module	V	V																		V	V										V	V	V	V																				
D	2016	Spark	Powertrain	1.2L LKY Engine Control Module	V																			V	V																																		
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																		
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V														
D	2016	Spark	Powertrain	Fuel Injector Control Module		V																		V	V																																		
D	2016	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V									V												
D	2016	Spark	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					
D	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
D	2016	Spark	Chassis	Power Steering Control Module	V	V																			V																																		
D	2016	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
D	2016	Spark	Body	Body Control Module	V	V																		V	V																																		
D	2016	Spark	Body	Body Control Module	V	V																		V	V																																		
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																		
D	2016	Spark	Body	Instrument Cluster	V	V																		V	V																																		
D	2016	Spark	Body	Instrument Cluster	V	V																		V	V																																		
D	2016	Spark	Body	Radio	V	V																		V	V																																		
D	2016	Spark	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
D	2016	Spark	Body	Keyless Entry Control Module		V																																																					
D	2016	Spark EV	Powertrain	Engine Control Module	V																			V	V								V																											
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module	V	V																		V	V										V																								
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V	V																		V	V																																		
D	2016	Spark EV	Powertrain	Drive Motor Control Module		V																			V																																		
D	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																		
D	2016	Spark EV	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
D	2016	Spark EV	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
D	2016	Spark EV	Chassis	Power Steering Control Module	V	V																			V																																		
D	2016	Spark EV	Body	Body Control Module	V	V																		V	V																																		
D	2016	Spark EV	Body	Pedestrian Alert Sound Control Module	V	V																			V																																		
D	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
D	2016	Spark EV	Body	Passenger Presence Module	V	V																			V																																		
D	2016	Spark EV	Body	Instrument Cluster	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2016	Spark EV	Body	Radio	V	V																		V	V																																			
D	2016	Spark EV	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
D	2016	Spark EV	Body	HVAC Control Module	V	V																		V	V																																		
D	2016	Spark EV	Body	Electric A/C Compressor Control Module																					V																																		
D	2016	Spark EV	Body	Coolant Heater Control Module	V																				V																																		
D	2016	Spark EV	Body	Keyless Entry Control Module	V	V																			V																																		
D	2016	Spark EV	Body	Frontview Camera Module	V	V																		V	V																																		
D	2016	Spark EV	Body	Battery Charger Control Module		V																			V																																		
D	2016	Spark EV	Body	DC Charging Control Module		V																			V																																		
D	2016	Spark EV	Body	Battery Energy Control Module		V																			V																																		
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Automatic Transmission	V																			V	V					V	V	V								V	V	V	V															
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Manual Transmission	V																			V	V					V	V	V								V	V	V	V	V														
F	2010	Camaro	Powertrain	(V) 3.6L LLT Fuel Pump Control Module	V	V																		V	V							V		V																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V									V											
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission	V																			V	V	V			V	V	V	V	V													V											
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission	V																			V	V	V			V	V	V	V	V											V	V											
F	2010	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module	V	V																		V	V							V		V																								
F	2010	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module	V	V																		V	V										V	V	V	V									V											
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V											
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V											V	V											
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module	V	V																		V	V							V		V																								
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module	V	V																		V	V										V	V	V	V									V											
F	2010	Camaro	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V					
F	2010	Camaro	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
F	2010	Camaro	Chassis	Power Steering Control Module	V	V																			V																																		
F	2010	Camaro	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
F	2010	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																		
F	2010	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
F	2010	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
F	2010	Camaro	Body	Passenger Presence Module	V	V																			V																																		
F	2010	Camaro	Body	Instrument Cluster	V	V																		V	V																																		
F	2010	Camaro	Body	Auxiliary Gage Module	V	V																		V	V																																		
F	2010	Camaro	Body	Radio	V	V																		V	V																																		
F	2010	Camaro	Body	Multimedia Player Interface Module	V	V																			V																																		
F	2010	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module	V	V																		V	V												V										V											
F	2010	Camaro	Body	Mobile Telephone Control Module	V	V																		V	V																																		
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
F	2010	Camaro	Body	Remote Heater and Air Conditioning Control Module	V	V																		V	V																																		
F	2010	Camaro	Body	Front Seat Heating Control Module	V	V																		V	V																																		
F	2010	Camaro	Body	Folding Top Control Module	V	V																		V	V																																		
F	2010	Camaro	Body	Parking Assist Control Module	V	V																		V	V																																		
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Automatic Transmission	V																			V	V					V	V	V								V	V	V	V															
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Manual Transmission	V																			V	V					V	V	V								V	V	V	V	V														
F	2011	Camaro	Powertrain	(D) 3.6L LLT Fuel Pump Control Module	V	V																		V	V							V		V																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V									V											
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission	V																			V	V	V			V	V	V	V	V													V											
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission	V																			V	V	V			V	V	V	V	V											V	V											
F	2011	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module	V	V																		V	V							V		V																								
F	2011	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module	V	V																		V	V										V	V	V	V									V											
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V											

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V												V	V															
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module	V	V																	V	V							V		V																										
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module	V	V																	V	V										V	V	V	V									V														
F	2011	Camaro	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V							
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																	V	V
F	2011	Camaro	Chassis	Power Steering Control Module	V	V																		V																																		
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module	V																			V																																		
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																	V	V																																		
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																	V	V																																		
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
F	2011	Camaro	Body	Passenger Presence Module	V	V																		V																																		
F	2011	Camaro	Body	Instrument Cluster	V	V																	V	V																																		
F	2011	Camaro	Body	Head-Up Display Module	V																		V	V																																		
F	2011	Camaro	Body	Auxiliary Gage Module	V	V																	V	V																																		
F	2011	Camaro	Body	Headlamp Control Module	V	V																	V	V																																		
F	2011	Camaro	Body	Radio	V	V																	V	V																																		
F	2011	Camaro	Body	Multimedia Player Interface Module	V	V																		V																																		
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module	V	V																	V	V													V										V											
F	2011	Camaro	Body	Mobile Telephone Control Module	V	V																	V	V																																		
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9	V	V																	V	V																																		
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																		
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module	V	V																	V	V																																		
F	2011	Camaro	Body	Front Seat Heating Control Module	V	V																	V	V																																		
F	2011	Camaro	Body	Folding Top Control Module	V	V																	V	V																																		
F	2011	Camaro	Body	Parking Assist Control Module	V	V																	V	V																																		
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V							V	V	V	V		V														
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V							V	V	V	V	V	V														
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module	V	V																	V	V							V		V																									
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																	V	V										V	V	V	V									V													
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission	V																		V	V	V			V	V	V	V	V												V														
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission	V																		V	V	V			V	V	V	V	V											V	V														
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module	V	V																	V	V							V		V																									
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module	V	V																	V	V										V	V	V	V									V													
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V												V														
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V												V	V														
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module	V	V																	V	V							V		V																									
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module	V	V																	V	V										V	V	V	V									V													
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V												V														
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V												V	V														
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module	V	V									V								V	V							V																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module	V	V																	V	V										V	V	V	V									V													
F	2012	Camaro	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V							
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																	V	V
F	2012	Camaro	Chassis	Power Steering Control Module	V	V																		V																																		
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module	V																			V																																		
F	2012	Camaro	Chassis	Suspension Control Module	V	V																		V																																		
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																	V	V																																		
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																	V	V																																		
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
F	2012	Camaro	Body	Passenger Presence Module	V	V																		V																																		
F	2012	Camaro	Body	Instrument Cluster	V	V																	V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
F	2012	Camaro	Body	Head-Up Display Module	V																			V	V																																			
F	2012	Camaro	Body	Auxiliary Gage Module	V	V																		V	V																																			
F	2012	Camaro	Body	Headlamp Control Module	V	V																		V	V																																			
F	2012	Camaro	Body	Radio	V	V																		V	V																																			
F	2012	Camaro	Body	Multimedia Player Interface Module	V	V																			V																																			
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module	V	V																		V	V												V										V												
F	2012	Camaro	Body	Mobile Telephone Control Module	V	V																		V	V																																			
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module	V	V																		V	V																																			
F	2012	Camaro	Body	Front Seat Heating Control Module	V	V																		V	V																																			
F	2012	Camaro	Body	Folding Top Control Module	V	V																		V	V																																			
F	2012	Camaro	Body	Parking Assist Control Module	V	V																		V	V																																			
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V														
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V								V	V	V	V	V	V														
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow	V	V									V									V	V							V																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V								V														
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission	V																			V	V	V			V	V	V	V	V												V														
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission	V																			V	V	V			V	V	V	V	V											V	V														
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow	V	V									V									V	V							V																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module	V	V																		V	V										V	V	V	V								V														
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V														
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V											V	V														
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow	V	V									V									V	V							V																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module	V	V																		V	V										V	V	V	V								V														
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V														
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V											V	V														
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow	V	V									V									V	V							V																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module	V	V																		V	V										V	V	V	V								V														
F	2013	Camaro	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
F	2013	Camaro	Chassis	Power Steering Control Module	V	V																			V																																			
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
F	2013	Camaro	Chassis	Suspension Control Module	V	V																		V	V																																			
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
F	2013	Camaro	Body	Passenger Presence Module	V	V																			V																																			
F	2013	Camaro	Body	Instrument Cluster	V	V																		V	V																																			
F	2013	Camaro	Body	Head-Up Display Module	V																			V	V																																			
F	2013	Camaro	Body	Auxiliary Gage Module	V	V																		V	V																																			
F	2013	Camaro	Body	Headlamp Control Module	V	V																		V	V																																			
F	2013	Camaro	Body	Radio	V	V																		V	V																																			
F	2013	Camaro	Body	Multimedia Player Interface Module	V	V																			V																																			
F	2013	Camaro	Body	Mobile Telephone Control Module	V	V																		V	V																																			
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
F	2013	Camaro	Body	HVAC Control Module	V	V																		V	V																																		
F	2013	Camaro	Body	Front Seat Heating Control Module	V	V																		V	V																																		
F	2013	Camaro	Body	Folding Top Control Module	V	V																		V	V																																		
F	2013	Camaro	Body	Parking Assist Control Module	V	V																		V	V																																		
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V								V	V	V	V		V												
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V									V	V	V	V	V	V												
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission	V																			V	V	V			V	V	V	V	V													V												
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission	V																			V	V	V			V	V	V	V	V											V	V												
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V												
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V											V	V												
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V												
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V											V	V												
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V												
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V											V	V												
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V		V																								
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow	V	V									V									V	V							V																										
F	2014	Camaro	Powertrain	Transmission Control Module	V	V																		V	V										V	V	V	V								V												
F	2014	Camaro	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
F	2014	Camaro	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																															V	V	
F	2014	Camaro	Chassis	Power Steering Control Module	V	V																			V																																		
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
F	2014	Camaro	Chassis	Suspension Control Module	V	V																			V																																		
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																		
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
F	2014	Camaro	Body	Passenger Presence Module	V	V																			V																																		
F	2014	Camaro	Body	Instrument Cluster	V	V																		V	V																																		
F	2014	Camaro	Body	Head-Up Display Module	V																			V	V																																		
F	2014	Camaro	Body	Auxiliary Gage Module	V	V																		V	V																																		
F	2014	Camaro	Body	Headlamp Control Module	V	V																		V	V																																		
F	2014	Camaro	Body	Radio	V	V																		V	V																																		
F	2014	Camaro	Body	Mobile Telephone Control Module	V	V																		V	V																																		
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
F	2014	Camaro	Body	HVAC Control Module	V	V																		V	V																																		
F	2014	Camaro	Body	Front Seat Heating Control Module	V	V																		V	V																																		
F	2014	Camaro	Body	Folding Top Control Module	V	V																		V	V																																		
F	2014	Camaro	Body	Parking Assist Control Module	V																			V	V																																		
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module	V																			V	V				V	V	V	V	V												V												
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module	V	V																		V	V										V	V	V	V								V												
F	2014	SS	Powertrain	Chassis Control Module	V	V																		V	V							V		V																								
F	2014	SS	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
F	2014	SS	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
F	2014	SS	Chassis	Power Steering Control Module	V	V																			V																																		
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
F	2014	SS	Body	Body Control Module	V	V																		V	V																																		
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
F	2014	SS	Body	Passenger Presence Module	V	V																			V																																		
F	2014	SS	Body	Instrument Cluster	V	V																		V	V																																		
F	2014	SS	Body	Head-Up Display Module	V																			V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
F	2014	SS	Body	Radio Control	V																			V	V																																			
F	2014	SS	Body	HVAC Control	V	V																		V	V																																		
F	2014	SS	Body	Headlamp Control Module	V	V																		V	V																						V												
F	2014	SS	Body	Trailer Interface Control Module	V	V																		V	V																																		
F	2014	SS	Body	Radio	V	V																		V	V																																		
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
F	2014	SS	Body	HVAC Control Module	V	V																		V	V																																		
F	2014	SS	Body	Seat Memory Control Module - Driver	V																																																					
F	2014	SS	Body	Keyless Entry Control Module	V	V																		V	V																																		
F	2014	SS	Body	Right Side Object Detection Control Module	V																			V	V																																		
F	2014	SS	Body	Left Side Object Detection Control Module	V																			V	V																																		
F	2014	SS	Body	Parking Assist Control Module	V	V																		V	V																																		
F	2014	SS	Body	Frontview Camera Module	V	V																		V	V																																		
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V								V	V	V	V		V												
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V									V	V	V	V	V	V												
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission	V																			V	V	V			V	V	V	V	V													V												
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission	V																			V	V	V			V	V	V	V	V												V	V												
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V												
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V												
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V												
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V												
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V												
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V												
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V		V																								
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow	V	V									V									V	V							V																										
F	2015	Camaro	Powertrain	Transmission Control Module	V	V																		V	V										V	V	V	V									V												
F	2015	Camaro	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
F	2015	Camaro	Chassis	Power Steering Control Module	V	V																			V																																		
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
F	2015	Camaro	Chassis	Suspension Control Module	V	V																			V																																		
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																		
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
F	2015	Camaro	Body	Passenger Presence Module	V	V																			V																																		
F	2015	Camaro	Body	Instrument Cluster	V	V																		V	V																																		
F	2015	Camaro	Body	Head-Up Display Module	V																			V	V																																		
F	2015	Camaro	Body	Auxiliary Gage Module	V	V																		V	V																																		
F	2015	Camaro	Body	Headlamp Control Module	V	V																		V	V																																		
F	2015	Camaro	Body	Radio	V	V																		V	V																																		
F	2015	Camaro	Body	Mobile Telephone Control Module	V	V																		V	V																																		
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																		
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
F	2015	Camaro	Body	HVAC Control Module	V	V																		V	V																																		
F	2015	Camaro	Body	Front Seat Heating Control Module	V	V																		V	V																																		
F	2015	Camaro	Body	Folding Top Control Module	V	V																		V	V																																		
F	2015	Camaro	Body	Parking Assist Control Module	V																			V	V																																		
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V	V												
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
F	2015	SS	Powertrain	Fuel Injector Control Module		V																		V	V																																		
F	2015	SS	Powertrain	Chassis Control Module	V	V									V									V	V							V																											
F	2015	SS	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
F	2015	SS	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
F	2015	SS	Chassis	Power Steering Control Module	V	V																			V																																	
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
F	2015	SS	Chassis	Suspension Control Module	V	V																			V																																	
F	2015	SS	Body	Body Control Module	V	V																		V	V																																	
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
F	2015	SS	Body	Passenger Presence Module	V	V																			V																																	
F	2015	SS	Body	Instrument Cluster	V	V																		V	V																																	
F	2015	SS	Body	Head-Up Display Module	V																			V	V																																	
F	2015	SS	Body	Radio Control	V																			V	V																																	
F	2015	SS	Body	HVAC Control	V	V																		V	V																																	
F	2015	SS	Body	Headlamp Control Module	V	V																		V	V																					V													
F	2015	SS	Body	Trailer Interface Control Module	V	V																		V	V																																	
F	2015	SS	Body	Radio	V	V																		V	V																																	
F	2015	SS	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
F	2015	SS	Body	HVAC Control Module	V	V																		V	V																																	
F	2015	SS	Body	Seat Memory Control Module - Driver	V																																																				
F	2015	SS	Body	Keyless Entry Control Module	V	V																		V	V																																	
F	2015	SS	Body	Right Side Object Detection Control Module	V																			V	V																																	
F	2015	SS	Body	Left Side Object Detection Control Module	V																			V	V																																	
F	2015	SS	Body	Parking Assist Control Module	V	V																		V	V																																	
F	2015	SS	Body	Frontview Camera Module	V	V																		V	V																																	
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V	V												
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V												
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V												
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V							V	V	V	V	V	V												
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V												
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V												
F	2016	Camaro	Powertrain	Transmission Control Module	V	V																		V	V									V	V	V	V		V																		
F	2016	Camaro	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V				V	
F	2016	Camaro	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
F	2016	Camaro	Chassis	Power Steering Control Module	V	V																			V																																	
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
F	2016	Camaro	Chassis	Suspension Control Module	V	V																		V	V																																	
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																	
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																	
F	2016	Camaro	Body	Serial Data Gateway Module	V																				V																																	
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
F	2016	Camaro	Body	Passenger Presence Module	V	V																			V																																	
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																		V	V																																	
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)	V	V																		V	V																																	
F	2016	Camaro	Body	Head-Up Display Module	V																			V	V																																	
F	2016	Camaro	Body	Auxiliary Gage Module	V	V																		V	V																																	
F	2016	Camaro	Body	Radio Controls	V																				V																																	
F	2016	Camaro	Body	HVAC Controls	V																			V	V																																	
F	2016	Camaro	Body	Vehicle Performance Data Recorder	V																				V																																	
F	2016	Camaro	Body	Radio	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
F	2016	Camaro	Body	Amplifier	V	V																			V																																			
F	2016	Camaro	Body	Media Disc Player	V	V																		V	V																																			
F	2016	Camaro	Body	Human Machine Interface Control Module	V	V																		V	V																						V													
F	2016	Camaro	Body	Navigation Control Module	V	V																			V																																			
F	2016	Camaro	Body	Mobile Telephone Control Module	V	V																		V	V																																			
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)	V	V																		V	V																																			
F	2016	Camaro	Body	Seat Memory Control Module - Driver	V																																																							
F	2016	Camaro	Body	Folding Top Control Module	V	V																		V	V																																			
F	2016	Camaro	Body	Keyless Entry Control Module	V	V																		V	V																																			
F	2016	Camaro	Body	Right Side Object Detection Control Module	V																			V	V																																			
F	2016	Camaro	Body	Left Side Object Detection Control Module	V																			V	V																																			
F	2016	Camaro	Body	Parking Assist Control Module	V																			V	V																																			
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V													V														
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V	V														
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module	V	V																		V	V									V	V	V	V										V												
F	2016	SS	Powertrain	Fuel Injector Control Module		V																		V	V																																			
F	2016	SS	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
F	2016	SS	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
F	2016	SS	Chassis	Power Steering Control Module	V	V																			V																																			
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
F	2016	SS	Chassis	Suspension Control Module	V	V																		V	V																																			
F	2016	SS	Body	Body Control Module	V	V																		V	V																																			
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
F	2016	SS	Body	Passenger Presence Module	V	V																			V																																			
F	2016	SS	Body	Instrument Cluster	V	V																		V	V																																			
F	2016	SS	Body	Head-Up Display Module	V																			V	V																																			
F	2016	SS	Body	Radio Control	V																			V	V																																			
F	2016	SS	Body	HVAC Control	V	V																		V	V																																			
F	2016	SS	Body	Trailer Interface Control Module	V	V																		V	V																																			
F	2016	SS	Body	Radio	V	V																		V	V																																			
F	2016	SS	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
F	2016	SS	Body	HVAC Control Module	V	V																		V	V																																			
F	2016	SS	Body	Seat Memory Control Module - Driver	V	V																		V	V																																			
F	2016	SS	Body	Keyless Entry Control Module	V	V																		V	V																																			
F	2016	SS	Body	Right Side Object Detection Control Module	V																			V	V																																			
F	2016	SS	Body	Left Side Object Detection Control Module	V																			V	V																																			
F	2016	SS	Body	Parking Assist Control Module	V	V																		V	V																																			
F	2016	SS	Body	Frontview Camera Module	V	V																		V	V																																			
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module	V																			V	V				V	V	V	V													V														
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																												
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V																
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V	V																											
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V																
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
G	2016	Malibu	Powertrain	Fuel Injector Control Module	V	V																		V	V												V										V	V	V	V	V	V				V		
G	2016	Malibu	Powertrain	Chassis Control Module	V	V																		V	V																																			
G	2016	Malibu	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2016	Malibu	Chassis	Parking Brake Control Module	V	V																			V																						V						V	V	V	V		
G	2016	Malibu	Chassis	Power Steering Control Module	V	V																			V																																	
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																	
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																	
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
G	2016	Malibu	Body	Passenger Presence Module	V	V																			V																																	
G	2016	Malibu	Body	Instrument Cluster	V	V																		V	V																																	
G	2016	Malibu	Body	Headlamp Control Module	V	V																		V	V																						V											
G	2016	Malibu	Body	Radio	V	V																		V	V																																	
G	2016	Malibu	Body	Digital Radio Receiver Control Module	V	V																			V																																	
G	2016	Malibu	Body	Multimedia Player Interface Module	V	V																			V																																	
G	2016	Malibu	Body	Mobile Telephone Control Module	V	V																		V	V																																	
G	2016	Malibu	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)	V	V																		V	V																																	
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																	
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																	
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)	V	V																		V	V																																	
G	2016	Malibu	Body	Seat Memory Control Module	V																																																				
G	2016	Malibu	Body	Front Seat Heating Control Module	V	V																		V	V																																	
G	2016	Malibu	Body	Rear Seat Heating Control Module	V	V																		V	V																																	
G	2016	Malibu	Body	Keyless Entry Control Module	V	V																		V	V																																	
G	2016	Malibu	Body	Left Side Object Detection Control Module	V																			V	V																																	
G	2016	Malibu	Body	Parking Assist Control Module	V																			V	V																																	
G	2016	Malibu	Body	Frontview Camera Module	V	V																		V	V																																	
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module	V	V	V			V			V			V	V	V			V			V	V			V				V																										
H	2010	Sail	Powertrain	Transmission Control Module	V																			V	V										V																							
H	2010	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																													V					
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module	V	V	V			V			V			V	V	V			V			V	V			V				V																										
H	2011	Sail	Powertrain	Transmission Control Module	V																			V	V										V																							
H	2011	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																													V					
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																	
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																	
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																										
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																										
H	2012	Sail	Powertrain	Transmission Control Module	V																			V	V										V																							
H	2012	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																													V					
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																										
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																										
H	2013	Sail	Powertrain	Transmission Control Module	V																			V	V										V																							
H	2013	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					
H	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																	
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																	
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																										
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																										
H	2014	Sail	Powertrain	Transmission Control Module	V																			V	V										V																							
H	2014	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					
H	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
H	2015	Sail	Powertrain	1.3L LEW Engine Control Module	V																			V	V																																	
H	2015	Sail	Powertrain	1.5L L2B Engine Control Module	V																			V	V																																	
H	2015	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V					
H	2015	Sail	Chassis	Power Steering Control Module	V	V																			V																																	
H	2015	Sail	Body	Body Control Module	V	V																		V	V																																	
H	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
H	2015	Sail	Body	Radio/HVAC Control	V	V																		V	V																																	
H	2015	Sail	Body	HVAC Control Module	V	V																		V	V																																	
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission	V																			V	V																																	
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission	V																			V	V																																	
H	2016	Sail	Powertrain	1.5L L2B Transmission Control Module	V	V																		V	V										V	V	V	V																					
H	2016	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V					
H	2016	Sail	Chassis	Power Steering Control Module	V	V																			V																																	
H	2016	Sail	Body	Body Control Module	V	V																		V	V																																	
H	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
H	2016	Sail	Body	Radio/HVAC Control	V	V																		V	V																																	
H	2016	Sail	Body	Radio	V	V																		V	V																																	
H	2016	Sail	Body	HVAC Control Module	V	V																		V	V																																	
J	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V																		V	V																				V													
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V																		V	V																				V													
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																				V													
J	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module	V	V	V						V			V					V			V																				V													
J	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module	V	V	V						V			V					V			V																				V													
J	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																				V													
J	2004	Optra	Powertrain	ML4/MLQ 4 Speed Automatic	V	V																		V	V																																	
J	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																	
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes	V	V																		V	V																																	
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control No	V	V																		V	V																																	
J	2004	Optra	Body	Remote Function Actuation		V																																																				
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V							V			V					V			V	V							V												V													
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module	V	V																		V											V	V																					
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel	V	V							V			V					V			V	V							V												V													
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel Transmission Control Module	V	V																		V											V	V																					
J	2004	Cavalier	Chassis	Anti-lock Brake System	V																			V																																	
J	2004	Cavalier	Body	Body Control Module	V	V																		V	V																																	
J	2004	Cavalier	Body	Digital Radio Receiver	V	V																			V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2004	Cavalier	Body	Instrument Panel Cluster	V	V																		V																																						
J	2004	Cavalier	Body	Radio	V	V																		V																																					
J	2004	Cavalier	Body	Supplemental Inflatable Restraint	V	V																																																							
J	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V																		V	V																					V															
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V							V				V							V	V																					V															
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																					V															
J	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module	V	V	V						V			V					V			V																					V															
J	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module	V	V	V						V			V					V			V																					V															
J	2005	Optra	Powertrain	ML4/MLQ 4 Speed Automatic	V	V																		V	V																																				
J	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																				
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes	V	V																		V	V																																				
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control No	V	V																		V	V																																				
J	2005	Optra	Body	Remote Function Actuation		V																																																							
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V							V			V					V			V	V						V														V															
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module	V	V																		V										V	V																									
J	2005	Cavalier	Chassis	Anti-lock Brake System	V																			V																																					
J	2005	Cavalier	Body	Body Control Module	V	V																		V	V																																				
J	2005	Cavalier	Body	Digital Radio Receiver	V	V																			V																																				
J	2005	Cavalier	Body	Instrument Panel Cluster	V	V																		V																																					
J	2005	Cavalier	Body	Radio	V	V																		V																																					
J	2005	Cavalier	Body	Supplemental Inflatable Restraint	V	V																																																						
J	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																					V															
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V											V							V	V																					V															
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																					V															
J	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module	V	V	V						V			V					V			V																					V															
J	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module	V	V	V						V			V					V			V																					V															
J	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V					V			V																					V															
J	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																					V															
J	2006	ALL	Powertrain	ML4/MLQ 4 Speed Automatic	V	V																		V	V																																				
J	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																				
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																				
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																				
J	2006	ALL	Body	Remote Function Actuation		V																																																							
J	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																				
J	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																					V															
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V											V							V	V																					V															
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																					V															
J	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module	V	V	V						V			V	V				V			V																					V															
J	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																					V															
J	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V	V		V																					V															
J	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																												
J	2007	ALL	Powertrain	4 Speed Automatic	V	V																		V	V																																				
J	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																				
J	2007	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V									V	V	V																								
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																				
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No	V	V																		V	V																																				
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																				
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No	V	V																		V	V																																				
J	2007	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																				
J	2007	ALL	Body	Remote Function Actuation		V																																																						
J	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																				V														
J	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module	V	V											V							V	V																				V														
J	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V											V							V	V																				V														
J	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module	V	V	V						V			V	V				V			V																				V														
J	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																				V														
J	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																										
J	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V	V		V																				V														
J	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																										
J	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed	V	V																		V	V																																	
J	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																	
J	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																	
J	2008	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V										V	V	V																					
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																	
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																	
J	2008	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																	
J	2008	ALL	Body	Remote Function Actuation		V																																																				
J	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																	
J	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																				V														
J	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module	V	V											V							V	V																				V														
J	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V											V							V	V																				V														
J	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module	V	V	V						V			V	V				V			V																				V														
J	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																				V														
J	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																										
J	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V	V		V																				V														
J	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed	V	V																		V	V																																	
J	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																	
J	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																	
J	2009	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V										V	V	V																					
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																	
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																	
J	2009	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																	
J	2009	ALL	Body	Remote Function Actuation		V																																																			
J	2009	ALL	Body	Supplemental Inflatable Restraint	V																				V																																	
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission	V																			V	V																																	
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																	
J	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																										
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V											V															
J	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
J	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																										
J	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V											V															
J	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission	V																			V	V																																	
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission	V																			V	V																																	
J	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
J	2010	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V						
J	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
J	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
J	2010	Cruze	Body	Body Control Module	V	V																		V	V																																	
J	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
J	2010	Cruze	Body	Passenger Presence Module	V	V																			V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2010	Cruze	Body	Instrument Cluster	V	V																		V	V																																				
J	2010	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																				
J	2010	Cruze	Body	Radio	V	V																		V	V																																				
J	2010	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																				
J	2010	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																				
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																				
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																				
J	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)	V	V																		V	V																																				
J	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)	V	V																		V	V																																				
J	2010	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																				
J	2010	Cruze	Body	Parking Assist Control Module	V	V																		V	V																																				
J	2010	Cruze	Body	Steering Column Lock Control Module	V	V																			V																																				
J	2010	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																					V														
J	2010	Other	Powertrain	(6)1.6L L4 LXT Engine Control Module	V	V											V							V	V																					V														
J	2010	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																					V														
J	2010	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																											
J	2010	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V	V				V			V																					V														
J	2010	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																				
J	2010	Other	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																				
J	2010	Other	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V										V	V	V																							
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																				
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																				
J	2010	Other	Chassis	Tire Pressure Monitor	V	V																			V																																				
J	2010	Other	Body	Remote Function Actuation		V																																																						
J	2010	Other	Body	Supplemental Inflatable Restraint	V	V																			V																																				
J	2010	Other	Body	Supplemental Inflatable Restraint	V																				V																																				
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																												
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V															
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module	V	V																		V	V							V		V																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																			
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																			
J	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																												
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V															
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission	V																			V	V																					V														
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission	V																			V	V																					V	V														
J	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																			
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																			
J	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																												
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V															
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission	V																			V	V																						V														
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission	V																			V	V																					V	V														
J	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V					V		V																												
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																			V	V					V		V													V															
J	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module	V	V																		V	V							V		V																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission	V																			V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission	V																			V	V																																				
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V																													
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V															
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2011	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V						
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
J	2011	Cruze	Body	Body Control Module	V	V																		V	V																																	
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
J	2011	Cruze	Body	Passenger Presence Module	V	V																			V																																	
J	2011	Cruze	Body	Instrument Cluster	V	V																		V	V																																	
J	2011	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																	
J	2011	Cruze	Body	Radio	V	V																		V	V																																	
J	2011	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																	
J	2011	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																	
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)	V	V																		V	V																																	
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)	V	V																		V	V																																	
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)	V	V																		V	V																																	
J	2011	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																	
J	2011	Cruze	Body	Parking Assist Control Module	V	V																		V	V																																	
J	2011	Cruze	Body	Steering Column Lock Control Module	V	V																			V																																	
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																			V															
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module	V	V											V							V	V																			V															
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																			V															
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																											
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V	V				V			V																			V															
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																	
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																	
J	2011	Other	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V									V	V	V																					
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																	
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																	
J	2011	Other	Chassis	Tire Pressure Monitor	V	V																			V																																	
J	2011	Other	Body	Remote Function Actuation		V																																																				
J	2011	Other	Body	Supplemental Inflatable Restraint	V																				V																																	
J	2011	Other	Body	Supplemental Inflatable Restraint	V	V																			V																																	
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																	
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																	
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																	
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																	
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V															
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V														
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V														
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module	V	V																	V	V			V	V	V	V					V	V	V	V	V																		
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V														
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission	V																		V	V			V	V	V	V														V														
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module	V	V																	V	V			V	V	V	V					V	V	V	V	V																		
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V														
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V														
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
J	2012	Aveo	Powertrain	Fuel Pump Control Module	V	V																	V	V						V		V																									
J	2012	Aveo	Powertrain	Fuel Injector Control Module		V																	V	V																																	
J	2012	Aveo	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V						
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V
J	2012	Aveo	Chassis	Electric Power Steering Control Module	V	V																		V																																
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																			V																																
J	2012	Aveo	Body	Body Control Module Hatchback	V	V																	V	V																																
J	2012	Aveo	Body	Body Control Module Sedan	V	V																	V	V																																
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																
J	2012	Aveo	Body	Passenger Presence Module	V	V																		V																																
J	2012	Aveo	Body	Instrument Cluster	V	V																	V	V																																
J	2012	Aveo	Body	Radio	V	V																	V	V																																
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module	V	V																	V	V																																
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																	V	V																																
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																	V	V																																
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																	V	V																																
J	2012	Aveo	Body	Front Seat Heating Control Module	V	V																	V	V																																
J	2012	Aveo	Body	Parking Assist Control Module	V	V																		V																																
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																		V	V																																
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																		V	V																																
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																		V	V																																
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																		V	V																																
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V														
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V														
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V														
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V														
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
J	2012	Cobalt	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V						
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V
J	2012	Cobalt	Chassis	Electric Power Steering Control Module	V	V																		V																																
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module	V																			V																																
J	2012	Cobalt	Body	Body Control Module	V	V																	V	V																																
J	2012	Cobalt	Body	Passenger Presence Module	V	V																		V																																
J	2012	Cobalt	Body	Instrument Cluster	V	V																	V	V																																
J	2012	Cobalt	Body	Radio	V	V																	V	V																																
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module	V	V																	V	V																																
J	2012	Cobalt	Body	Telematics Communication Interface Control Module	V	V																	V	V																																
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)	V	V																	V	V																																

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
J	2012	Cobalt	Body	Front Seat Heating Control Module	V	V																		V	V																																			
J	2012	Cobalt	Body	Parking Assist Control Module	V	V																			V																																			
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V																
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module	V	V																		V	V							V		V																											
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																			
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																			
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																													
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission	V	V	V		V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V																
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission	V																			V	V																					V														
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission	V																			V	V																			V	V															
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																			
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																			
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																			
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																			
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V															
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission	V																			V	V																				V															
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission	V																			V	V																			V	V															
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V																			V	V																																			
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V																			V	V																																			
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V					V		V																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																			V	V					V		V												V																
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module	V	V																		V	V							V		V																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission	V																			V	V																																			
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission	V																			V	V																																			
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V																													
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V																
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2012	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V								
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
J	2012	Cruze	Body	Body Control Module Hatchback	V	V																		V	V																																		
J	2012	Cruze	Body	Body Control Module Sedan	V	V																		V	V																																		
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
J	2012	Cruze	Body	Passenger Presence Module	V	V																			V																																		
J	2012	Cruze	Body	Instrument Cluster	V	V																		V	V																																		
J	2012	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																		
J	2012	Cruze	Body	Radio	V	V																		V	V																																		
J	2012	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																		
J	2012	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																		
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																				
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)	V	V																		V	V																																				
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)	V	V																		V	V																																				
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)	V	V																		V	V																																				
J	2012	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																				
J	2012	Cruze	Body	Parking Assist Control Module	V	V																		V	V																																				
J	2012	Cruze	Body	Steering Column Lock Control Module	V	V																			V																																				
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																				V																
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module	V	V											V							V	V																				V																
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																				V																	
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																													
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																				
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																				
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V									V	V	V																									
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																				
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																				
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor	V	V																			V																																				
J	2012	Sonic (First Gen)	Body	Remote Function Actuation		V																																																							
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint	V																				V																																				
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint	V	V																			V																																				
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V														V																
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V			V	V	V	V													V	V																
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module	V	V																		V	V							V		V																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																				
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																				
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																				
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																				
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V														V																
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V			V	V	V	V													V	V																
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module	V	V																		V	V							V		V																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V														V																
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V			V	V	V	V													V	V																
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module	V	V																		V	V							V		V																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V														V																
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																			V	V			V	V	V	V													V	V																
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V														V																
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission	V																			V	V			V	V	V	V													V	V																
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V														V																
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																			V	V			V	V	V	V													V	V																
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module	V	V																		V	V							V		V																											
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module	V	V																		V	V											V										V	V	V	V	V	V										
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																															V	V				
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module	V	V																			V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module Chassis Expansion CAN BUS	V																				V																																				
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module High Speed CAN Bus	V																				V																																			
J	2012	Sonic (Second Gen)	Body	Body Control Module Hatchback	V	V																		V	V																																			
J	2012	Sonic (Second Gen)	Body	Body Control Module Sedan	V	V																		V	V																																			
J	2012	Sonic (Second Gen)	Body	Passenger Presence Module	V	V																			V																																			
J	2012	Sonic (Second Gen)	Body	Instrument Cluster	V	V																		V	V																																			
J	2012	Sonic (Second Gen)	Body	Radio	V	V																		V	V																																			
J	2012	Sonic (Second Gen)	Body	Telematic Vehicle Localization and Immobilization Control Module	V	V																		V	V																																			
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																			
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
J	2012	Sonic (Second Gen)	Body	Front Seat Heating Control Module	V	V																		V	V																																			
J	2012	Sonic (Second Gen)	Body	Parking Assist Control Module	V	V																			V																																			
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V															V													
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V													
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V															V													
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V													
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																			
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																			
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V															V													
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V													
J	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V															V													
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V													
J	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V															V													
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V													
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Aveo	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																									
J	2013	Aveo	Powertrain	Fuel Injector Control Module		V																		V	V																																			
J	2013	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
J	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
J	2013	Aveo	Chassis	Electric Power Steering Control Module	V	V																			V																																			
J	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
J	2013	Aveo	Body	Body Control Module Hatchback	V	V																		V	V																																			
J	2013	Aveo	Body	Body Control Module Sedan	V	V																		V	V																																			
J	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
J	2013	Aveo	Body	Passenger Presence Module	V	V																			V																																			
J	2013	Aveo	Body	Instrument Cluster	V	V																		V	V																																			
J	2013	Aveo	Body	Radio	V	V																		V	V																																			
J	2013	Aveo	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
J	2013	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																			
J	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
J	2013	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
J	2013	Aveo	Body	Front Seat Heating Control Module	V	V																		V	V																																			
J	2013	Aveo	Body	Parking Assist Control Module	V	V																			V																																			
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																		V	V																																			
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V														
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission	V																		V	V				V	V	V	V												V	V													
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V													
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V													
J	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V													
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V												V	V													
J	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V													
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission	V																		V	V				V	V	V	V												V	V													
J	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2013	Cobalt	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V					
J	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V
J	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module	V																			V																																
J	2013	Cobalt	Body	Body Control Module	V	V																	V	V																																
J	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																
J	2013	Cobalt	Body	Instrument Cluster	V	V																	V	V																																
J	2013	Cobalt	Body	Radio	V	V																	V	V																																
J	2013	Cobalt	Body	Telematics Communication Interface Control Module	V	V																	V	V																																
J	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)	V	V																	V	V																																
J	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																	V	V																																
J	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)	V	V																	V	V																																
J	2013	Cobalt	Body	Front Seat Heating Control Module	V	V																	V	V																																
J	2013	Cobalt	Body	Parking Assist Control Module	V	V																	V	V																																
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																		V	V																				V													
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																		V	V																				V	V													
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																									
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V													
J	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																									
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V													
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter	V	V																		V																																
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump	V	V																	V	V							V		V																							
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V								V	V							V																									
J	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V	V	V																																
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V	V	V																																
J	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V						V	V																									
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V	V						V	V												V													
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V																															
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V	V																			V													
J	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V	V	V																																
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V	V	V																																
J	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V			V	V																																
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V			V	V																																
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V						V	V																									
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V	V						V	V												V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V																																		
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V																			V															
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V															
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																									
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V															
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																									
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V																											
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V															
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2013	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
J	2013	Cruze	Body	Body Control Module Hatchback	V	V																		V	V																																	
J	2013	Cruze	Body	Body Control Module Sedan	V	V																		V	V																																	
J	2013	Cruze	Body	Body Control Module Station Wagon	V	V																		V	V																																	
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
J	2013	Cruze	Body	Passenger Presence Module	V	V																			V																																	
J	2013	Cruze	Body	Instrument Cluster	V	V																		V	V																																	
J	2013	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																	
J	2013	Cruze	Body	Radio	V	V																		V	V																																	
J	2013	Cruze	Body	Digital Radio Receiver Control Module	V	V																			V																																	
J	2013	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																	
J	2013	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																	
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																	
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																	
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																	
J	2013	Cruze	Body	Front Seat Heating Control Module	V	V																		V	V																																	
J	2013	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																	
J	2013	Cruze	Body	Right Side Object Detection Control Module	V																			V	V																																	
J	2013	Cruze	Body	Left Side Object Detection Control Module	V																			V	V																																	
J	2013	Cruze	Body	Parking Assist Control Module	V	V																		V	V																																	
J	2013	Cruze	Body	Steering Column Lock Control Module	V	V																			V																																	
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																			V															
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module	V	V											V							V	V																			V															
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																			V															
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																											
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																	
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																	
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V									V	V	V																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																			
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																			
J	2013	Sonic (First Gen)	Chassis	Tire Pressure Monitor	V	V																			V																																			
J	2013	Sonic (First Gen)	Body	Remote Function Actuation		V																																																						
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint	V																				V																																			
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint	V	V																			V																																			
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module	V	V																		V	V							V		V																									
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																		
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																		
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module	V	V																		V	V							V		V																									
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Fuel Pump Control Module	V	V																		V	V							V		V																									
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module	V	V																		V	V							V		V																									
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																			V	V					V		V																											
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																			V	V					V		V													V													
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Fuel Pump Control Module	V	V																		V	V							V		V																									
J	2013	Sonic (Second Gen)	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
J	2013	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
J	2013	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
J	2013	Sonic (Second Gen)	Body	Body Control Module Hatchback	V	V																		V	V																																		
J	2013	Sonic (Second Gen)	Body	Body Control Module Sedan	V	V																		V	V																																		
J	2013	Sonic (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
J	2013	Sonic (Second Gen)	Body	Passenger Presence Module	V	V																			V																																		
J	2013	Sonic (Second Gen)	Body	Instrument Cluster	V	V																		V	V																																		
J	2013	Sonic (Second Gen)	Body	Radio	V	V																		V	V																																		
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
J	2013	Sonic (Second Gen)	Body	Front Seat Heating Control Module	V	V																		V	V																																			
J	2013	Sonic (Second Gen)	Body	Parking Assist Control Module	V	V																			V																																			
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																			
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																			
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V													V																
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V													V																
J	2013	Spin	Powertrain	1.8L LJ1 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V													V																
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission	V																			V	V			V	V	V	V													V																
J	2013	Spin	Powertrain	1.8L LMD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2013	Spin	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V								
J	2013	Spin	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
J	2013	Spin	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
J	2013	Spin	Body	Body Control Module	V	V																		V	V																																			
J	2013	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
J	2013	Spin	Body	Instrument Cluster	V	V																		V	V																																			
J	2013	Spin	Body	Radio	V	V																		V	V																																			
J	2013	Spin	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																			
J	2013	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
J	2013	Spin	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
J	2013	Spin	Body	Parking Assist Control Module	V	V																			V																																			
J	2014	Aveo	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V													V																
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V			V	V	V	V												V	V																
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V													V																
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V			V	V	V	V												V	V																
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																			
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																			
J	2014	Aveo	Powertrain	1.4L L95 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																												
J	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module	V	V																		V	V									V	V	V																								
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission	V																			V	V			V	V		V													V																
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission	V																			V	V			V	V		V													V																
J	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module	V	V																		V	V									V	V	V																								
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V													V																
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission	V																			V	V			V	V	V	V												V	V																
J	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V													V																
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V			V	V	V	V												V	V																
J	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V													V																
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V			V	V	V	V												V	V																
J	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V													V																
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V			V	V	V	V												V	V																
J	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module	V	V																		V	V										V	V	V																								
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																												
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V										V	V	V																								
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2014	Aveo	Powertrain	Chassis Control Module	V	V																		V	V							V		V																										
J	2014	Aveo	Powertrain	Fuel Injector Control Module		V																		V	V																																			
J	2014	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
J	2014	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
J	2014	Aveo	Chassis	Power Steering Control Module	V	V																			V																																		
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
J	2014	Aveo	Body	Body Control Module Hatchback	V	V																		V	V																																		
J	2014	Aveo	Body	Body Control Module Sedan	V	V																		V	V																																		
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																		
J	2014	Aveo	Body	Instrument Cluster	V	V																		V	V																																		
J	2014	Aveo	Body	Radio	V	V																		V	V																																		
J	2014	Aveo	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
J	2014	Aveo	Body	Front Seat Heating Control Module	V	V																		V	V																																		
J	2014	Aveo	Body	Keyless Entry Control Module		V																																																					
J	2014	Aveo	Body	Parking Assist Control Module	V	V																			V																																		
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
J	2014	Cobalt	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
J	2014	Cobalt	Body	Body Control Module	V	V																		V	V																																		
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
J	2014	Cobalt	Body	Instrument Cluster	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2014	Cobalt	Body	Radio	V	V																		V	V																																			
J	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
J	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
J	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
J	2014	Cobalt	Body	Front Seat Heating Control Module	V	V																		V	V																																		
J	2014	Cobalt	Body	Parking Assist Control Module	V	V																		V	V																																		
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V													
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V													
J	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V													
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter	V	V																			V																																
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																								
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																	
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																	
J	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V												V													
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V																																
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V																			V													
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter	V	V																			V																																
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																								
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V													
J	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																	
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																	
J	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																	
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																	
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																	
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																	
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																										
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V												V													
J	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V																																	
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V																			V													
J	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V													
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter	V	V																			V																																
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																								
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V															
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter	V	V																			V																																			
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																										
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																												
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V																													
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V														V														
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module	V	V	V	V		V	V	V		V	V	V	V		V	V	V			V	V						V	V	V																											
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter	V	V																			V																																		
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																										
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module		V								V										V	V																																		
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module	V	V																		V	V										V		V																						
J	2014	Cruze	Powertrain	Fuel Injector Control Module		V																		V	V																																		
J	2014	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V					
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
J	2014	Cruze	Chassis	Power Steering Control Module	V	V																			V																																		
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
J	2014	Cruze	Body	Body Control Module Hatchback	V	V																		V	V																																		
J	2014	Cruze	Body	Body Control Module Sedan	V	V																		V	V																																		
J	2014	Cruze	Body	Body Control Module Station Wagon	V	V																		V	V																																		
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
J	2014	Cruze	Body	Passenger Presence Module	V	V																			V																																		
J	2014	Cruze	Body	Instrument Cluster	V	V																		V	V																																		
J	2014	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																		
J	2014	Cruze	Body	Radio	V	V																		V	V																																		
J	2014	Cruze	Body	Digital Radio Receiver Control Module	V	V																			V																																		
J	2014	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																		
J	2014	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																		
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																		
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
J	2014	Cruze	Body	Front Seat Heating Control Module	V	V																		V	V																																		
J	2014	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																		
J	2014	Cruze	Body	Right Side Object Detection Control Module	V																			V	V																																		
J	2014	Cruze	Body	Left Side Object Detection Control Module	V																			V	V																																		
J	2014	Cruze	Body	Parking Assist Control Module	V	V																		V	V																																		
J	2014	Cruze	Body	Steering Column Lock Control Module	V	V																			V																																		
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V														
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V														
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module	V	V																		V	V							V		V																										
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																		
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																		
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V														
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V														
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V															
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V														
J	2014	Sonic	Powertrain	1.4L LDD Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
J	2014	Sonic	Powertrain	1.4L LDD Chassis Control Module	V	V																	V	V						V		V																								
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V												
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V												
J	2014	Sonic	Powertrain	1.4L LUJ Chassis Control Module	V	V																	V	V						V		V																							
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
J	2014	Sonic	Powertrain	(B) 1.4L LUV Chassis Control Module	V	V																	V	V						V		V																							
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V												
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V												
J	2014	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
J	2014	Sonic	Powertrain	(C) 1.6L LDE Chassis Control Module	V	V																	V	V						V		V																							
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V												
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V												
J	2014	Sonic	Powertrain	1.6L LED Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V												
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V												
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V												
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V												
J	2014	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
J	2014	Sonic	Powertrain	(H) 1.8L LUW Chassis Control Module	V	V																	V	V						V		V																							
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																		V	V				V		V																									
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																		V	V				V		V													V													
J	2014	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
J	2014	Sonic	Powertrain	(G) 1.8L LWE Chassis Control Module	V	V																	V	V						V		V																							
J	2014	Sonic	Powertrain	Fuel Injector Control Module		V																	V	V																																
J	2014	Sonic	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V					
J	2014	Sonic	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																															V	V
J	2014	Sonic	Chassis	Power Steering Control Module	V	V																		V																															
J	2014	Sonic	Chassis	Steering Wheel Angle Sensor Module	V																			V																															
J	2014	Sonic	Body	Body Control Module Hatchback	V	V																	V	V																															
J	2014	Sonic	Body	Body Control Module Sedan	V	V																	V	V																															
J	2014	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																															
J	2014	Sonic	Body	Passenger Presence Module	V	V																		V																															
J	2014	Sonic	Body	Instrument Cluster	V	V																	V	V																															
J	2014	Sonic	Body	Radio	V	V																	V	V																															
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 9	V	V																	V	V																															
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																															
J	2014	Sonic	Body	HVAC Control Module Heater Only (C41)	V	V																	V	V																															
J	2014	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																	V	V																															
J	2014	Sonic	Body	HVAC Control Module Single Zone (C60)	V	V																	V	V																															
J	2014	Sonic	Body	Front Seat Heating Control Module	V	V																	V	V																															
J	2014	Sonic	Body	Parking Assist Control Module	V	V																		V																															
J	2014	Sonic	Body	Frontview Camera Module	V	V																	V	V																															
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V												
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																		V	V			V	V	V	V														V												
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission	V																		V	V																															

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
J	2014	Spin	Powertrain	1.5L L2B Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
J	2014	Spin	Powertrain	1.8L LJ1 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
J	2014	Spin	Powertrain	1.8L LMD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2014	Spin	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
J	2014	Spin	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
J	2014	Spin	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
J	2014	Spin	Body	Body Control Module	V	V																		V	V																																		
J	2014	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
J	2014	Spin	Body	Instrument Cluster	V	V																		V	V																																		
J	2014	Spin	Body	Radio	V	V																		V	V																																		
J	2014	Spin	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
J	2014	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
J	2014	Spin	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
J	2014	Spin	Body	Parking Assist Control Module	V	V																			V																																		
J	2015	Aveo	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V					V		V	V																																		
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V														
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V														
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																		
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																		
J	2015	Aveo	Powertrain	1.4L L95 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
J	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module	V	V																		V	V										V	V	V																						
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission	V																			V	V				V	V		V													V														
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission	V																			V	V				V	V		V													V														
J	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module	V	V																		V	V										V	V	V																						
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V														
J	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V														
J	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V														
J	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V														
J	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
J	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module	V	V																		V	V										V	V	V																						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																													
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V									V	V	V																								
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2015	Aveo	Powertrain	Chassis Control Module	V	V																		V	V							V	V																										
J	2015	Aveo	Powertrain	Fuel Injector Control Module		V																		V	V																																		
J	2015	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
J	2015	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																	
J	2015	Aveo	Chassis	Power Steering Control Module	V	V																			V																																	
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
J	2015	Aveo	Body	Body Control Module Hatchback	V	V																		V	V																																	
J	2015	Aveo	Body	Body Control Module Sedan	V	V																		V	V																																	
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																	
J	2015	Aveo	Body	Instrument Cluster	V	V																		V	V																																	
J	2015	Aveo	Body	Radio	V	V																		V	V																																	
J	2015	Aveo	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																	
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																	
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																	
J	2015	Aveo	Body	Front Seat Heating Control Module	V	V																		V	V																																	
J	2015	Aveo	Body	Keyless Entry Control Module		V																																																				
J	2015	Aveo	Body	Parking Assist Control Module	V	V																			V																																	
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																	
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																	
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2015	Cobalt	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V						
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
J	2015	Cobalt	Body	Body Control Module	V	V																		V	V																																	
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
J	2015	Cobalt	Body	Instrument Cluster	V	V																		V	V																																	
J	2015	Cobalt	Body	Radio	V	V																		V	V																																	
J	2015	Cobalt	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
J	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
J	2015	Cobalt	Body	Front Seat Heating Control Module	V	V																		V	V																																		
J	2015	Cobalt	Body	Parking Assist Control Module	V	V																			V																																		
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V													
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V													
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																									
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																										
J	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V													
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																								
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																	
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																	
J	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V												V													
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V																																
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V																			V													
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																								
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V													
J	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission	V																			V	V																																	
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission	V																			V	V																																	
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																	
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																	
J	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																	
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																	
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																	
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																	
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																										
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V												V													
J	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V																																	
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V																			V													
J	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V													
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter	V	V																			V																																
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
J	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V															
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
J	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V																											
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V														
J	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module	V	V	V	V		V	V	V		V	V	V	V		V	V	V			V	V						V	V	V																										
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module		V								V										V	V																																	
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module	V	V																		V	V									V		V																						
J	2015	Cruze	Powertrain	Fuel Injector Control Module		V																		V	V																																	
J	2015	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V					
J	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
J	2015	Cruze	Chassis	Power Steering Control Module	V	V																			V																																	
J	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
J	2015	Cruze	Body	Body Control Module Hatchback	V	V																		V	V																																	
J	2015	Cruze	Body	Body Control Module Sedan	V	V																		V	V																																	
J	2015	Cruze	Body	Body Control Module Station Wagon	V	V																		V	V																																	
J	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
J	2015	Cruze	Body	Passenger Presence Module	V	V																			V																																	
J	2015	Cruze	Body	Instrument Cluster	V	V																		V	V																																	
J	2015	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																	
J	2015	Cruze	Body	Radio	V	V																		V	V																																	
J	2015	Cruze	Body	Digital Radio Receiver Control Module	V	V																			V																																	
J	2015	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																	
J	2015	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																	
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
J	2015	Cruze	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																	
J	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																	
J	2015	Cruze	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																	
J	2015	Cruze	Body	Front Seat Heating Control Module	V	V																		V	V																																	
J	2015	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																	
J	2015	Cruze	Body	Right Side Object Detection Control Module	V																			V	V																																	
J	2015	Cruze	Body	Left Side Object Detection Control Module	V																			V	V																																	
J	2015	Cruze	Body	Parking Assist Control Module	V	V																			V																																	
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V													
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																	
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																	
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																	
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																	
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2015	Sonic	Powertrain	1.4L L2N Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Sonic	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Sonic	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Sonic	Powertrain	1.6L LED Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																			V	V					V		V																											
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																			V	V					V		V													V														
J	2015	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2015	Sonic	Powertrain	Chassis Control Module	V	V																		V	V							V		V																									
J	2015	Sonic	Powertrain	Fuel Injector Control Module		V																		V	V																																		
J	2015	Sonic	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
J	2015	Sonic	Chassis	Power Steering Control Module	V	V																			V																																	
J	2015	Sonic	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
J	2015	Sonic	Body	Body Control Module Hatchback	V	V																		V	V																																	
J	2015	Sonic	Body	Body Control Module Sedan	V	V																		V	V																																	
J	2015	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
J	2015	Sonic	Body	Passenger Presence Module	V	V																			V																																	
J	2015	Sonic	Body	Instrument Cluster	V	V																		V	V																																	
J	2015	Sonic	Body	Radio	V	V																		V	V																																	
J	2015	Sonic	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
J	2015	Sonic	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																	
J	2015	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																	
J	2015	Sonic	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																	
J	2015	Sonic	Body	Front Seat Heating Control Module	V	V																		V	V																																	
J	2015	Sonic	Body	Parking Assist Control Module	V	V																			V																																	
J	2015	Sonic	Body	Frontview Camera Module	V	V																		V	V																																	
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																	
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																	
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
J	2015	Spin	Powertrain	1.5L L2B Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V															
J	2015	Spin	Powertrain	1.8L LJ1 Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V															
J	2015	Spin	Powertrain	1.8L LMD Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
J	2015	Spin	Chassis	Electronic Brake Control Module	V	V																	V	V												V										V	V	V	V	V	V						
J	2015	Spin	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
J	2015	Spin	Body	Body Control Module	V	V																	V	V																																	
J	2015	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																	
J	2015	Spin	Body	Instrument Cluster	V	V																	V	V																																	
J	2015	Spin	Body	Radio	V	V																	V	V																																	
J	2015	Spin	Body	Telematics Communication Interface Control Module	V	V																	V	V																																	
J	2015	Spin	Body	HVAC Control Module Heater Only (C41)	V	V																	V	V																																	
J	2015	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																	V	V																																	
J	2015	Spin	Body	HVAC Control Module Single Zone (C60)	V	V																	V	V																																	
J	2015	Spin	Body	Front Seat Heating Control Module	V	V																	V	V																																	
J	2015	Spin	Body	Parking Assist Control Module	V	V																		V																																	
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V														
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																		V	V																																	
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																		V	V																																	
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																		V	V																																	
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																		V	V																																	
J	2016	Aveo	Powertrain	1.4L L95 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																										
J	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module	V	V																		V	V									V	V	V																					
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
J	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
J	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
J	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
J	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																										
J	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module	V	V																	V	V									V	V	V																							
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
J	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
J	2016	Aveo	Powertrain	1.6L LED Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
J	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
J	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																										
J	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																	V	V									V	V	V																							
J	2016	Aveo	Powertrain	Chassis Control Module	V	V																	V	V							V		V																									
J	2016	Aveo	Chassis	Electronic Brake Control Module	V	V																	V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2016	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V							
J	2016	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V							
J	2016	Aveo	Chassis	Power Steering Control Module	V	V																			V																																		
J	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
J	2016	Aveo	Body	Body Control Module Hatchback	V	V																		V	V																																		
J	2016	Aveo	Body	Body Control Module Sedan	V	V																		V	V																																		
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																		
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
J	2016	Aveo	Body	Instrument Cluster	V	V																		V	V																																		
J	2016	Aveo	Body	Radio	V	V																		V	V																																		
J	2016	Aveo	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
J	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
J	2016	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
J	2016	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
J	2016	Aveo	Body	Front Seat Heating Control Module	V	V																		V	V																																		
J	2016	Aveo	Body	Parking Assist Control Module	V																			V	V																																		
J	2016	Aveo	Body	Keyless Entry Control Module		V																																																					
J	2016	Aveo	Body	Frontview Camera Module	V	V																		V	V																																		
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V															V											
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V											
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V															V											
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission	V																			V	V				V	V	V	V															V											
J	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V															V											
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V											
J	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V															V											
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V											
J	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
J	2016	Cobalt	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V							
J	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
J	2016	Cobalt	Body	Body Control Module	V	V																		V	V																																		
J	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module	V																																																				
J	2016	Cobalt	Body	Instrument Cluster	V	V																		V	V																																		
J	2016	Cobalt	Body	Radio Other	V	V																		V	V																																		
J	2016	Cobalt	Body	Radio (IOB)	V	V																		V	V																																		
J	2016	Cobalt	Body	Radio (UF7)	V	V																		V	V																																		
J	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
J	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
J	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
J	2016	Cobalt	Body	Front Seat Heating Control Module	V	V																		V	V																																		
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V														V												
J	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V														V												
J	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V																			V	V																																		
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V																			V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																											
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V														
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V																			V	V																																		
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V																			V	V																			V														
J	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission	V																			V	V																																		
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission	V																			V	V																																		
J	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V																			V	V																																		
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V																			V	V																																		
J	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																											
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V														
J	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V																			V	V																																		
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V																			V	V																			V														
J	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V				V		V																											
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V				V		V													V														
J	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V				V		V																											
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V				V		V													V														
J	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																											
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V													V														
J	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2016	Cruze	Powertrain	Fuel Injector Control Module		V																		V	V																																		
J	2016	Cruze	Powertrain	Chassis Control Module	V	V									V									V	V							V																											
J	2016	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V							
J	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
J	2016	Cruze	Chassis	Power Steering Control Module	V	V																			V																																	
J	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
J	2016	Cruze	Body	Body Control Module Hatchback	V	V																		V	V																																	
J	2016	Cruze	Body	Body Control Module Sedan	V	V																		V	V																																	
J	2016	Cruze	Body	Body Control Module Station Wagon	V	V																		V	V																																	
J	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
J	2016	Cruze	Body	Passenger Presence Module	V	V																			V																																	
J	2016	Cruze	Body	Instrument Cluster	V	V																		V	V																																	
J	2016	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																	
J	2016	Cruze	Body	Radio Other	V	V																		V	V																																	
J	2016	Cruze	Body	Radio (UF7)	V	V																		V	V																																	
J	2016	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																	
J	2016	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																	
J	2016	Cruze	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
J	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																	
J	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)	V	V																		V	V																																	
J	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																	
J	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																	
J	2016	Cruze	Body	Front Seat Heating Control Module	V	V																		V	V																																	
J	2016	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2016	Cruze	Body	Right Side Object Detection Control Module	V																		V	V																																						
J	2016	Cruze	Body	Left Side Object Detection Control Module	V																		V	V																																						
J	2016	Cruze	Body	Parking Assist Control Module	V	V																	V	V																																						
J	2016	Cruze	Body	Steering Column Lock Control Module	V	V																		V																																						
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V																
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V															
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																		V	V																																						
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																		V	V																																						
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																		V	V																																						
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																		V	V																																						
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V																
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V															
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																						
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V																
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V															
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																						
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V																
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V															
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																						
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V															V																
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																		V	V				V	V	V	V														V	V															
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																						
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V																
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																		V	V				V	V	V	V														V	V															
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																						
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V																
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission	V																		V	V				V	V	V	V														V	V															
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																						
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V																
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																		V	V				V	V	V	V														V	V															
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																						
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																		V	V					V		V																														
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																		V	V					V		V													V																
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																						
J	2016	Sonic	Powertrain	Chassis Control Module	V	V																	V	V							V		V																												
J	2016	Sonic	Powertrain	Fuel Injector Control Module		V																	V	V																																					
J	2016	Sonic	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V							
J	2016	Sonic	Chassis	Power Steering Control Module	V	V																		V																																				
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module	V																			V																																				
J	2016	Sonic	Body	Body Control Module Hatchback	V	V																	V	V																																				
J	2016	Sonic	Body	Body Control Module Sedan	V	V																	V	V																																				
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																				
J	2016	Sonic	Body	Passenger Presence Module	V	V																		V																																				
J	2016	Sonic	Body	Instrument Cluster	V	V																	V	V																																				
J	2016	Sonic	Body	Radio Other	V	V																	V	V																																				
J	2016	Sonic	Body	Radio (UF7)	V	V																	V	V																																				
J	2016	Sonic	Body	Radio (UH7)	V	V																	V	V																																				
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7	V	V																	V	V																																				
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																				
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																	V	V																																				
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)	V	V																	V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																				
J	2016	Sonic	Body	Front Seat Heating Control Module	V	V																		V	V																																			
J	2016	Sonic	Body	Parking Assist Control Module	V	V																		V	V																																			
J	2016	Sonic	Body	Frontview Camera Module	V	V																		V	V																																			
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
J	2016	Spin	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
J	2016	Spin	Body	Body Control Module	V	V																		V	V																																			
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
J	2016	Spin	Body	Instrument Cluster	V	V																		V	V																																			
J	2016	Spin	Body	Radio	V	V																		V	V																																			
J	2016	Spin	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																			
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
J	2016	Spin	Body	Front Seat Heating Control Module	V	V																		V	V																																			
J	2016	Spin	Body	Parking Assist Control Module	V																			V	V																																			
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V														
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module	V	V											V							V	V																				V														
K	2006	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																			
K	2006	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2006	ALL	Body	Remote Function Actuation		V																																																					
K	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V														
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module	V	V											V							V	V																				V														
K	2007	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																			
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module	V	V																		V	V																																			
K	2007	ALL	Chassis	Teves Electronic Brake Control Module	V	V																		V	V																																			
K	2007	ALL	Body	Remote Function Actuation		V																																																					
K	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V														
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module	V	V											V							V	V																				V														
K	2008	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																			
K	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2008	ALL	Body	Remote Function Actuation		V																																																					
K	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V														
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																				V														
K	2009	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2009	ALL	Body	Remote Function Actuation		V																																																					
K	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
K	2010	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V													
K	2010	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																				V													
K	2010	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																	
K	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																	
K	2010	ALL	Body	Remote Function Actuation		V																																																				
K	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																	
K	2011	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V													
K	2011	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																				V													
K	2011	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																	
K	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																	
K	2011	ALL	Body	Remote Function Actuation		V																																																				
K	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																	
K	2012	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V													
K	2012	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																				V													
K	2012	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																	
K	2012	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																	
K	2012	ALL	Body	Remote Function Actuation		V																																																				
K	2012	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																	
K	2013	Onix	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V													
K	2013	Onix	Powertrain	(0)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																				V													
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V														V													
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission	V																			V	V			V	V	V	V														V													
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V														V													
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission	V																			V	V			V	V	V	V														V													
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V														V													
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission	V																			V	V			V	V	V	V														V													
K	2013	Onix	Powertrain	Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
K	2013	Onix	Powertrain	Transmission Control Module	V	V																		V	V																																	
K	2013	Onix	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
K	2013	Onix	Chassis	Electronic Brake Control Module	V	V																		V	V																																	
K	2013	Onix	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																															V	V
K	2013	Onix	Chassis	Steering Wheel Angle Sensor Module	V																				V																																
K	2013	Onix	Body	Body Control Module	V	V																		V	V																																	
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
K	2013	Onix	Body	Instrument Cluster	V	V																		V	V																																	
K	2013	Onix	Body	Radio	V	V																		V	V																																	
K	2013	Onix	Body	Parking Assist Control Module	V	V																		V	V																																	
K	2013	Onix	Body	Remote Function Actuation		V																																																				
K	2013	Prisma	Powertrain	Engine Control Module	V																			V	V			V	V	V	V														V													
K	2013	Prisma	Powertrain	Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
K	2013	Prisma	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
K	2013	Prisma	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																															V	V
K	2013	Prisma	Chassis	Steering Wheel Angle Sensor Module	V																				V																																
K	2013	Prisma	Body	Body Control Module	V	V																		V	V																																	
K	2013	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
K	2013	Prisma	Body	Instrument Cluster	V	V																		V	V																																	
K	2013	Prisma	Body	Radio	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2013	Prisma	Body	Parking Assist Control Module	V	V																			V																																			
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
K	2014	Onix	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V						
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
K	2014	Onix	Body	Body Control Module	V	V																		V	V																																	
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
K	2014	Onix	Body	Instrument Cluster	V	V																		V	V																																	
K	2014	Onix	Body	Radio	V	V																		V	V																																	
K	2014	Onix	Body	Parking Assist Control Module	V	V																		V	V																																	
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
K	2014	Prisma	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V						
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
K	2014	Prisma	Body	Body Control Module	V	V																		V	V																																	
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
K	2014	Prisma	Body	Instrument Cluster	V	V																		V	V																																	
K	2014	Prisma	Body	Radio	V	V																		V	V																																	
K	2014	Prisma	Body	Parking Assist Control Module	V	V																		V	V																																	
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
K	2015	Onix	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V						
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
K	2015	Onix	Body	Body Control Module	V	V																		V	V																																	
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
K	2015	Onix	Body	Instrument Cluster	V	V																		V	V																																	
K	2015	Onix	Body	Radio	V	V																		V	V																																	
K	2015	Onix	Body	Parking Assist Control Module	V	V																			V																																	
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V															
K	2015	Prisma	Powertrain	1.4L LKJ Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V															
K	2015	Prisma	Powertrain	1.4L LKK Transmission Control Module	V	V																	V	V				V	V	V	V			V	V	V	V	V	V																				
K	2015	Prisma	Chassis	Electronic Brake Control Module	V	V																	V	V												V										V	V	V	V	V	V						
K	2015	Prisma	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
K	2015	Prisma	Body	Body Control Module	V	V																	V	V																																	
K	2015	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																	
K	2015	Prisma	Body	Instrument Cluster	V	V																	V	V																																	
K	2015	Prisma	Body	Radio	V	V																	V	V																																	
K	2015	Prisma	Body	Parking Assist Control Module	V	V																		V																																	
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V															
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V															
K	2016	Onix	Powertrain	1.4L LKJ Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V															
K	2016	Onix	Powertrain	1.4L LKK Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
K	2016	Onix	Chassis	Electronic Brake Control Module	V	V																	V	V												V										V	V	V	V	V	V						
K	2016	Onix	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
K	2016	Onix	Body	Body Control Module	V	V																	V	V																																	
K	2016	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																	
K	2016	Onix	Body	Instrument Cluster	V	V																	V	V																																	
K	2016	Onix	Body	Radio	V	V																	V	V																																	
K	2016	Onix	Body	Parking Assist Control Module	V																		V	V																																	
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V															
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V															
K	2016	Prisma	Powertrain	1.4L LKJ Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V															
K	2016	Prisma	Powertrain	1.4L LKK Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
K	2016	Prisma	Chassis	Electronic Brake Control Module	V	V																	V	V												V										V	V	V	V	V	V						
K	2016	Prisma	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
K	2016	Prisma	Body	Body Control Module	V	V																	V	V																																	
K	2016	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																	
K	2016	Prisma	Body	Instrument Cluster	V	V																	V	V																																	
K	2016	Prisma	Body	Radio	V	V																	V	V																																	
K	2016	Prisma	Body	HVAC Control Module	V	V																	V	V																																	
K	2016	Prisma	Body	Front Seat Heating Control Module	V	V																	V	V																																	
K	2016	Prisma	Body	Parking Assist Control Module	V																		V	V																																	
L	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																			V															
L	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V																		V																																	
L	2004	ALL	Powertrain	Transmission Control Module	V	V																		V																																	
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes	V	V																		V																																	
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control No	V	V																		V																																	
L	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																		V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2004	ALL	Body	Supplemental Inflatable Restraint	V																				V																																					
L	2004	ALL	Body	ISU	V	V																		V																																					
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																						V															
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V																		V	V																																					
L	2005	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																					
L	2005	ALL	Chassis	Anti-lock Brake System	V	V																		V	V																																					
L	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																					
L	2005	ALL	Body	Supplemental Inflatable Restraint	V																				V																																					
L	2005	ALL	Body	ISU	V	V																		V																																					
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																						V															
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V											V							V	V																					V															
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																					
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes	V	V																		V	V																																					
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No	V	V																		V	V																																					
L	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																					
L	2006	ALL	Body	Supplemental Inflatable Restraint	V																				V																																					
L	2006	ALL	Body	ISU	V	V																		V																																					
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V											V							V	V																					V															
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																					V															
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module	V	V													V					V	V					V	V																														
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module	V	V											V							V	V																					V															
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module	V	V											V							V	V																					V															
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector	V	V																		V	V																																					
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V										V	V	V																								
L	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
L	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																					
L	2007	ALL	Body	ISU	V	V																		V																																					
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																					V															
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module	V	V													V					V	V						V	V																													
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																					V															
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V										V	V	V																								
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed	V	V																		V											V	V	V																								
L	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
L	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																					
L	2008	ALL	Body	ISU	V	V																		V																																					
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																					V															
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module	V	V													V					V	V						V	V																													
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																					V															
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed	V	V																		V											V	V	V																								
L	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
L	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																					
L	2009	ALL	Body	ISU	V	V																		V																																					
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																					V															
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																					V															
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module	V	V													V					V	V						V	V																													
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed	V	V																		V											V	V	V																								
L	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
L	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																					
L	2010	ALL	Body	ISU	V	V																		V																																					
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																					V															
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																					V															

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module	V	V													V					V	V						V	V																												
L	2011	ALL	Powertrain	Transmission Control Module 6 Speed	V	V																		V											V	V	V																							
L	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
L	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																			
L	2011	ALL	Body	ISU	V	V																		V																																			
M	2004	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module	V	V																		V	V																				V														
M	2004	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module	V	V																		V	V																				V														
M	2004	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V																		V	V																																		
M	2004	ALL	Chassis	Anti-lock Brake System	V	V																		V	V																																			
M	2004	ALL	Body	Remote Function Actuation		V																																																					
M	2004	ALL	Body	Supplemental Inflatable Restraint	V																				V																																			
M	2005	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V														
M	2005	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																																		
M	2005	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																																		
M	2005	ALL	Chassis	Anti-lock Brake System	V	V																		V	V																																			
M	2005	ALL	Body	Remote Function Actuation		V																																																					
M	2005	ALL	Body	Supplemental Inflatable Restraint	V																				V																																			
M	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V														
M	2006	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																																		
M	2006	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																																		
M	2006	ALL	Chassis	Anti-lock Brake System	V	V																		V	V																																			
M	2006	ALL	Body	Remote Function Actuation		V																																																					
M	2006	ALL	Body	Supplemental Inflatable Restraint	V																				V																																			
M	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V														
M	2007	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																																		
M	2007	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																																		
M	2007	ALL	Chassis	Anti-lock Brake System	V	V																		V	V																																			
M	2007	ALL	Body	Remote Function Actuation		V																																																					
M	2007	ALL	Body	Supplemental Inflatable Restraint	V																				V																																			
M	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V														
M	2008	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																																		
M	2008	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																																		
M	2008	ALL	Chassis	Anti-lock Brake System	V	V																		V	V																																			
M	2008	ALL	Body	Remote Function Actuation		V																																																					
M	2008	ALL	Body	Supplemental Inflatable Restraint	V																				V																																			
M	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module	V	V											V							V	V																				V														
M	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																																		
M	2009	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module	V	V											V							V	V																																		
M	2009	ALL	Chassis	Anti-lock Brake System	V	V																		V	V																																			
M	2009	ALL	Body	Remote Function Actuation		V																																																					
M	2009	ALL	Body	Supplemental Inflatable Restraint	V																				V																																			
M	2010	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module	V	V																		V	V																																			
M	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module	V																			V	V																																			
M	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module	V																			V	V																																			
M	2010	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2010	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2010	Spark	Powertrain	Transmission Control Module	V	V																		V	V																																			
M	2010	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V										V													
M	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
M	2010	Spark	Chassis	Electric Power Steering Control Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
M	2010	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
M	2010	Spark	Body	Passenger Presence Module	V	V																			V																																		
M	2010	Spark	Body	Instrument Cluster	V	V																		V	V																																		
M	2011	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																			V														
M	2011	Caprice	Powertrain	Transmission Control Module	V	V																		V										V	V	V																						
M	2011	Caprice	Powertrain	Fuel Pump Control Module	V	V																		V	V																																		
M	2011	Caprice	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
M	2011	Caprice	Body	Body Control Module	V	V																		V	V																																		
M	2011	Caprice	Body	HVAC Control Module	V	V																		V	V																																		
M	2011	Caprice	Body	Instrument Panel Cluster	V	V																		V	V																																		
M	2011	Caprice	Body	Passenger Presence System	V	V																			V																																		
M	2011	Caprice	Body	Radio	V	V																		V	V																																		
M	2011	Caprice	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
M	2011	Caprice	Body	Supplemental Inflatable Restraint	V	V																			V																																		
M	2011	Caprice	Body	Theft Deterrent Module	V	V																			V																																		
M	2011	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module	V	V																		V	V																																		
M	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module	V																			V	V																																		
M	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module	V																			V	V																																		
M	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2011	Spark	Powertrain	Transmission Control Module	V	V																		V	V																																		
M	2011	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V											V											
M	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
M	2011	Spark	Chassis	Electric Power Steering Control Module	V	V																			V																																		
M	2011	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
M	2011	Spark	Body	Passenger Presence Module	V	V																			V																																		
M	2011	Spark	Body	Instrument Cluster	V	V																		V	V																																		
M	2012	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V						V													V														
M	2012	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																			V														
M	2012	Caprice	Powertrain	Transmission Control Module	V	V																		V										V	V	V																						
M	2012	Caprice	Powertrain	Fuel Pump Control Module	V	V																		V	V																																		
M	2012	Caprice	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
M	2012	Caprice	Body	Body Control Module	V	V																		V	V																																		
M	2012	Caprice	Body	HVAC Control Module	V	V																		V	V																																		
M	2012	Caprice	Body	Instrument Panel Cluster	V	V																		V	V																																		
M	2012	Caprice	Body	Passenger Presence System	V	V																			V																																		
M	2012	Caprice	Body	Radio	V	V																		V	V																																		
M	2012	Caprice	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
M	2012	Caprice	Body	Supplemental Inflatable Restraint	V	V																		V	V																																		
M	2012	Caprice	Body	Theft Deterrent Module	V	V																			V																																		
M	2012	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module	V	V																		V	V																																		
M	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module	V																			V	V																																		
M	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module	V																			V	V																																		
M	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2012	Spark	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
M	2012	Spark	Powertrain	1.2L L2E Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2012	Spark	Powertrain	Transmission Control Module	V	V																		V	V																																			
M	2012	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V										V												
M	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
M	2012	Spark	Chassis	Electric Power Steering Control Module	V	V																			V																																		
M	2012	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
M	2012	Spark	Body	Passenger Presence Module	V	V																			V																																		
M	2012	Spark	Body	Instrument Cluster	V	V																		V	V																																		
M	2013	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V													V													
M	2013	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																				V													
M	2013	Caprice	Powertrain	Transmission Control Module	V	V																		V										V	V	V																						
M	2013	Caprice	Powertrain	Fuel Pump Control Module	V	V																		V	V																																		
M	2013	Caprice	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
M	2013	Caprice	Body	Body Control Module	V	V																		V	V																																		
M	2013	Caprice	Body	HVAC Control Module	V	V																		V	V																																		
M	2013	Caprice	Body	Instrument Panel Cluster	V	V																		V	V																																		
M	2013	Caprice	Body	Passenger Presence System	V	V																			V																																		
M	2013	Caprice	Body	Radio	V	V																		V	V																																		
M	2013	Caprice	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
M	2013	Caprice	Body	Supplemental Inflatable Restraint	V	V																		V	V																																		
M	2013	Caprice	Body	Theft Deterrent Module	V	V																			V																																		
M	2013	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2013	Spark	Powertrain	1.0L LCP Transmission Control Module	V	V																		V	V																																		
M	2013	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2013	Spark	Powertrain	1.0L LMT Transmission Control Module	V	V																		V	V																																		
M	2013	Spark	Powertrain	1.19L LC5 Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module	V	V																		V	V																																		
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module	V	V																		V	V									V	V	V	V																						
M	2013	Spark	Powertrain	1.2L L2E Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2013	Spark	Powertrain	1.2L L2E Transmission Control Module	V	V																		V	V																																		
M	2013	Spark	Powertrain	1.2L LKY Engine Control Module	V																			V	V																																		
M	2013	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2013	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																		
M	2013	Spark	Powertrain	Fuel Injector Control Module	V	V																		V	V																																		
M	2013	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V										V												
M	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
M	2013	Spark	Chassis	Power Steering Control Module	V	V																			V																																		
M	2013	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
M	2013	Spark	Body	Body Control Module	V	V																		V	V																																		
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
M	2013	Spark	Body	Passenger Presence Module	V	V																			V																																		
M	2013	Spark	Body	Instrument Cluster	V	V																		V	V																																		
M	2013	Spark	Body	Radio	V	V																		V	V																																		
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
M	2014	Spark	Powertrain	0.8L LBF Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
M	2014	Spark	Powertrain	0.8L LBF Transmission Control Module	V	V																		V	V																																		
M	2014	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V	V			V			V			V	V					V		V	V																																		
M	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module	V	V																		V	V																																		
M	2014	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2014	Spark	Powertrain	1.0L LCP Transmission Control Module	V	V																		V	V																																		
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V														
M	2014	Spark	Powertrain	1.0L LFM Transmission Control Module	V	V																		V	V									V	V	V	V																					
M	2014	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2014	Spark	Powertrain	1.0L LMT Transmission Control Module	V	V																		V	V																																		
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																		
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V														
M	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module	V	V																		V	V									V	V	V	V																					
M	2014	Spark	Powertrain	1.2L LKY Engine Control Module	V																			V	V																																		
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																		
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																		
M	2014	Spark	Powertrain	Fuel Injector Control Module		V																		V	V																																		
M	2014	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V									V													
M	2014	Spark	Chassis	Electronic Brake Control Module	V	V																		V	V																											V						
M	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
M	2014	Spark	Chassis	Power Steering Control Module	V	V																			V																																	
M	2014	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
M	2014	Spark	Body	Body Control Module	V	V																		V	V																																	
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																	
M	2014	Spark	Body	Passenger Presence Module	V	V																			V																																	
M	2014	Spark	Body	Instrument Cluster	V	V																		V	V																																	
M	2014	Spark	Body	Radio	V	V																		V	V																																	
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
M	2014	Spark	Body	Keyless Entry Control Module		V																																																				
M	2014	Spark EV	Powertrain	Engine Control Module	V																			V	V								V																											
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module	V	V																		V	V										V																							
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V	V																		V	V																																	
M	2014	Spark EV	Powertrain	Drive Motor Control Module		V																			V																																	
M	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																	
M	2014	Spark EV	Chassis	Electronic Brake Control Module	V	V																		V	V																													V				
M	2014	Spark EV	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
M	2014	Spark EV	Chassis	Power Steering Control Module	V	V																			V																																	
M	2014	Spark EV	Body	Body Control Module	V	V																		V	V																																	
M	2014	Spark EV	Body	Pedestrian Alert Sound Control Module	V	V																			V																																	
M	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
M	2014	Spark EV	Body	Passenger Presence Module	V	V																			V																																	
M	2014	Spark EV	Body	Instrument Cluster	V	V																		V	V																																	
M	2014	Spark EV	Body	Radio	V	V																		V	V																																	
M	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
M	2014	Spark EV	Body	HVAC Control Module	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
M	2014	Spark EV	Body	Electric A/C Compressor Control Module																					V																																				
M	2014	Spark EV	Body	Coolant Heater Control Module	V																				V																																				
M	2014	Spark EV	Body	Keyless Entry Control Module	V	V																			V																																				
M	2014	Spark EV	Body	Battery Charger Control Module		V																			V																																				
M	2014	Spark EV	Body	DC Charging Control Module		V																			V																																				
M	2014	Spark EV	Body	Battery Energy Control Module		V																			V																																				
M	2015	Matiz	Powertrain	1.0L LA2 Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
M	2015	Matiz	Chassis	Electronic Brake Control Module	V	V																		V	V																													V						
M	2015	Matiz	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																			
M	2015	Matiz	Body	Keyless Entry Control Module		V																																																							
M	2015	Spark	Powertrain	0.8L LBF Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
M	2015	Spark	Powertrain	0.8L LBF Transmission Control Module	V	V																		V	V																																			
M	2015	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
M	2015	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2015	Spark	Powertrain	1.0L LCP Transmission Control Module	V	V																		V	V																																			
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																												
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V													V														
M	2015	Spark	Powertrain	1.0L LFM Transmission Control Module	V	V																		V	V										V	V	V	V																						
M	2015	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2015	Spark	Powertrain	1.0L LMT Transmission Control Module	V	V																		V	V																																			
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																			
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																												
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V													V														
M	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module	V	V																		V	V										V	V	V	V																						
M	2015	Spark	Powertrain	1.2L LKY Engine Control Module	V																			V	V																																			
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																			
M	2015	Spark	Powertrain	Fuel Injector Control Module		V																		V	V																																			
M	2015	Spark	Chassis	Electronic Brake Control Module	V	V																			V												V										V												
M	2015	Spark	Chassis	Electronic Brake Control Module	V	V																		V	V																													V						
M	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
M	2015	Spark	Chassis	Power Steering Control Module	V	V																			V																																			
M	2015	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
M	2015	Spark	Body	Body Control Module	V	V																		V	V																																			
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																			
M	2015	Spark	Body	Passenger Presence Module	V	V																			V																																			
M	2015	Spark	Body	Instrument Cluster	V	V																		V	V																																			
M	2015	Spark	Body	Instrument Cluster	V	V																		V	V																																			
M	2015	Spark	Body	Tire Pressure Indicator Module	V	V																			V																																			
M	2015	Spark	Body	Radio	V	V																		V	V																																			
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
M	2015	Spark	Body	Keyless Entry Control Module		V																																																						
M	2015	Spark EV	Powertrain	Engine Control Module	V																			V	V							V																													
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module	V	V																		V	V										V																									
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V	V																		V	V																																			
M	2015	Spark EV	Powertrain	Drive Motor Control Module		V																			V																																			
M	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
M	2015	Spark EV	Chassis	Electronic Brake Control Module	V	V																		V	V																											V							
M	2015	Spark EV	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
M	2015	Spark EV	Chassis	Power Steering Control Module	V	V																			V																																			
M	2015	Spark EV	Body	Body Control Module	V	V																		V	V																																			
M	2015	Spark EV	Body	Pedestrian Alert Sound Control Module	V	V																			V																																			
M	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
M	2015	Spark EV	Body	Passenger Presence Module	V	V																			V																																			
M	2015	Spark EV	Body	Instrument Cluster	V	V																		V	V																																			
M	2015	Spark EV	Body	Radio	V	V																		V	V																																			
M	2015	Spark EV	Body	HVAC Control Module	V	V																		V	V																																			
M	2015	Spark EV	Body	Electric A/C Compressor Control Module																					V																																			
M	2015	Spark EV	Body	Coolant Heater Control Module	V																				V																																			
M	2015	Spark EV	Body	Keyless Entry Control Module	V	V																			V																																			
M	2015	Spark EV	Body	Battery Charger Control Module		V																			V																																			
M	2015	Spark EV	Body	DC Charging Control Module		V																			V																																			
M	2015	Spark EV	Body	Battery Energy Control Module		V																			V																																			
M	2016	Spark	Powertrain	0.8L LBF Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
M	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module	V	V																		V	V																																			
M	2016	Spark	Powertrain	0.8L LBF Transmission Control Module	V	V																		V	V																																			
M	2016	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
M	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module	V	V																		V	V																																			
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V	V																											
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V	V											V															
M	2016	Spark	Powertrain	1.0L LCP Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2016	Spark	Powertrain	1.0L LCP Transmission Control Module	V	V																		V	V																																			
M	2016	Spark	Powertrain	1.0L LMT Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2016	Spark	Powertrain	1.0L LMT Transmission Control Module	V	V																		V	V																																			
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module	V	V																		V	V																																			
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																			
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V															
M	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module	V	V																		V	V										V	V	V	V																					
M	2016	Spark	Powertrain	1.2L LKY Engine Control Module	V																			V	V																																			
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V				V	V		V	V																																			
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module	V	V																		V	V																																			
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V	V																											
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V	V											V															
M	2016	Spark	Powertrain	Fuel Injector Control Module		V																		V	V																																			
M	2016	Spark	Chassis	Electronic Brake Control Module	V	V																			V													V										V											
M	2016	Spark	Chassis	Electronic Brake Control Module	V	V																		V	V																												V							
M	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
M	2016	Spark	Chassis	Power Steering Control Module	V	V																			V																																			
M	2016	Spark	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
M	2016	Spark	Body	Body Control Module	V	V																		V	V																																			
M	2016	Spark	Body	Body Control Module	V	V																		V	V																																			
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																			
M	2016	Spark	Body	Instrument Cluster	V	V																		V	V																																			
M	2016	Spark	Body	Instrument Cluster	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Right Front Solenoid Valves	ABS Left Front Solenoid Valves	ABS Right Rear Solenoid Valves	ABS Left Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
M	2016	Spark	Body	Radio	V	V																		V	V																																				
M	2016	Spark	Body	Telematics Communication Interface Control Module	V	V																		V	V																																				
M	2016	Spark	Body	Keyless Entry Control Module		V																																																							
M	2016	Spark EV	Powertrain	Engine Control Module	V																			V	V								V																												
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module	V	V																		V	V										V																									
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V	V																		V	V																																			
M	2016	Spark EV	Powertrain	Drive Motor Control Module		V																			V																																			
M	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																			
M	2016	Spark EV	Chassis	Electronic Brake Control Module	V	V																		V	V																													V						
M	2016	Spark EV	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
M	2016	Spark EV	Chassis	Power Steering Control Module	V	V																			V																																			
M	2016	Spark EV	Body	Body Control Module	V	V																		V	V																																			
M	2016	Spark EV	Body	Pedestrian Alert Sound Control Module	V	V																			V																																			
M	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
M	2016	Spark EV	Body	Passenger Presence Module	V	V																			V																																			
M	2016	Spark EV	Body	Instrument Cluster	V	V																		V	V																																			
M	2016	Spark EV	Body	Radio	V	V																		V	V																																			
M	2016	Spark EV	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
M	2016	Spark EV	Body	HVAC Control Module	V	V																		V	V																																			
M	2016	Spark EV	Body	Electric A/C Compressor Control Module																					V																																			
M	2016	Spark EV	Body	Coolant Heater Control Module	V																				V																																			
M	2016	Spark EV	Body	Keyless Entry Control Module	V	V																			V																																			
M	2016	Spark EV	Body	Frontview Camera Module	V	V																		V	V																																			
M	2016	Spark EV	Body	Battery Charger Control Module		V																			V																																			
M	2016	Spark EV	Body	DC Charging Control Module		V																			V																																			
M	2016	Spark EV	Body	Battery Energy Control Module		V																			V																																			
N	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V																		V	V																				V																
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V																		V	V																				V																
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																				V																
N	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module	V	V	V						V			V					V			V																				V																
N	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module	V	V	V						V			V					V			V																				V																
N	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																				V																
N	2004	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																			
N	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																			
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes	V	V																		V	V																																			
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control No	V	V																		V	V																																			
N	2004	Optra	Body	Remote Function Actuation		V																																																						
N	2004	Optra	Body	Supplemental Inflatable Restraint	V																				V																																			
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V							V			V					V			V	V						V												V																
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module	V	V																		V										V	V																							
N	2004	Classic	Chassis	Anti-lock Brake System	V																			V																																			
N	2004	Classic	Body	Body Control Module	V	V																		V																																			
N	2004	Classic	Body	Radio	V																			V																																			
N	2004	Classic	Body	Remote Function Actuation	V	V																																																				
N	2004	Classic	Body	Supplemental Inflatable Restraint	V	V																																																				
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Engine Control Module	V	V							V			V					V			V	V						V																												
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Transmission Control Module	V	V																		V										V	V																							
N	2004	Alero (Export)	Chassis	Anti-lock Brake System	V																			V																																			
N	2004	Alero (Export)	Body	Body Control Module	V	V																		V																																			
N	2004	Alero (Export)	Body	Instrument Panel Cluster	V	V																		V																																			
N	2004	Alero (Export)	Body	Radio	V	V																		V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
N	2004	Alero (Export)	Body	Supplemental Inflatable Restraint	V	V																																																								
N	2004	Alero (Export)	Body	Vehicle Theft Deterrent	V	V																																																								
N	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V																		V	V																					V															
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V							V				V							V	V																					V															
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																						V															
N	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module	V	V	V						V			V					V			V																						V															
N	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module	V	V	V						V			V					V			V																						V															
N	2005	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																						V															
N	2005	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																					
N	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																					
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes	V	V																		V	V																																					
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control No	V	V																		V	V																																					
N	2005	Optra	Body	Remote Function Actuation		V																																																								
N	2005	Optra	Body	Supplemental Inflatable Restraint	V																				V																																					
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V							V			V					V			V	V							V														V															
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module	V	V																		V										V	V																										
N	2005	Classic	Chassis	Anti-lock Brake System	V																			V																																					
N	2005	Classic	Body	Body Control Module	V	V																		V																																					
N	2005	Classic	Body	Radio	V																			V																																					
N	2005	Classic	Body	Remote Function Actuation	V	V																																																								
N	2005	Classic	Body	Supplemental Inflatable Restraint	V	V																																																								
N	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																					V															
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V											V							V	V																					V															
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																						V															
N	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V					V			V																						V															
N	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module	V	V	V						V			V					V			V																						V															
N	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module	V	V	V						V			V					V			V																						V															
N	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																						V															
N	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																					
N	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																					
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																					
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																					
N	2006	ALL	Body	Remote Function Actuation		V																																																								
N	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																																																								
N	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																					
N	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																					V															
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V											V							V	V																					V															
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																						V															
N	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																						V															
N	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module	V	V	V						V			V	V				V			V																						V															
N	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																													
N	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V	V		V																						V															
N	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																					
N	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																					
N	2007	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V									V	V	V																									
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																					
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No	V	V																		V	V																																					
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																					
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No	V	V																		V	V																																					
N	2007	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																					
N	2007	ALL	Body	Remote Function Actuation		V																																																								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
N	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																					
N	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																					V															
N	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V											V							V	V																					V															
N	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module	V	V											V							V	V																					V															
N	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																					V															
N	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module	V	V	V						V			V	V				V			V																					V															
N	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																												
N	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																												
N	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V	V				V			V																					V															
N	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed	V	V																		V	V																																			
N	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																			
N	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																			
N	2008	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V										V	V	V																						
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																			
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																			
N	2008	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																			
N	2008	ALL	Body	Remote Function Actuation		V																																																						
N	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																			
N	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																					V															
N	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V											V							V	V																					V															
N	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module	V	V											V							V	V																					V															
N	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																					V															
N	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module	V	V	V						V			V	V				V			V																					V															
N	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																												
N	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V	V				V			V																					V															
N	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed	V	V																		V	V																																			
N	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																			
N	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																			
N	2009	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V										V	V	V																						
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																			
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																			
N	2009	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																			
N	2009	ALL	Body	Remote Function Actuation		V																																																					
N	2009	ALL	Body	Supplemental Inflatable Restraint	V																				V																																			
N	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
N	2010	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																					V															
N	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module	V	V											V							V	V																					V															
N	2010	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																					V															
N	2010	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																												
N	2010	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V	V				V			V																					V															
N	2010	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																			
N	2010	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																			
N	2010	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V										V	V	V																						
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																			
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																			
N	2010	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																			
N	2010	ALL	Body	Remote Function Actuation		V																																																					
N	2010	ALL	Body	Remote Function Actuation	V	V																		V	V																																			
N	2010	ALL	Body	Supplemental Inflatable Restraint	V																				V																																			
N	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
N	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																					V															

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
N	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module	V	V											V							V	V																				V														
N	2011	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																					V														
N	2011	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																											
N	2011	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V	V				V			V																					V														
N	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																		
N	2011	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																		
N	2011	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V										V	V	V																						
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																		
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																		
N	2011	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																		
N	2011	ALL	Body	Remote Function Actuation		V																																																					
N	2011	ALL	Body	Supplemental Inflatable Restraint	V																				V																																		
N	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
N	2012	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																				V														
N	2012	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module	V	V											V							V	V																				V														
N	2012	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																					V														
N	2012	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																											
N	2012	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																		
N	2012	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																		
N	2012	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V										V	V	V																						
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																		
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																		
N	2012	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																		
N	2012	ALL	Body	Remote Function Actuation		V																																																				
N	2012	ALL	Body	Supplemental Inflatable Restraint	V																				V																																		
N	2012	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
N	2013	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V											V							V	V																				V														
N	2013	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module	V	V											V							V	V																				V														
N	2013	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																					V														
N	2013	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V												V					V	V						V	V																											
N	2013	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																		
N	2013	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																		
N	2013	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V										V	V	V																						
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control Yes	V	V																		V	V																																		
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control No	V	V																		V	V																																		
N	2013	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																		
N	2013	ALL	Body	Remote Function Actuation		V																																																				
N	2013	ALL	Body	Supplemental Inflatable Restraint	V																				V																																		
N	2013	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V								V	V	V	V		V														
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V								V	V	V	V		V														
N	2014	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V													
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V														
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V														
N	2014	Caprice	Powertrain	(2) 6.0L L77 Chassis Control Module	V	V																		V	V							V		V																									
N	2014	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module	V	V																		V	V										V	V	V	V										V													
N	2014	Caprice	Chassis	Electronic Brake Control Module	V	V																		V	V													V											V	V	V	V	V	V						
N	2014	Caprice	Chassis	Parking Brake Control Module	V	V																			V																							V							V	V	V	V		
N	2014	Caprice	Chassis	Power Steering Control Module	V	V																			V																																		
N	2014	Caprice	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
N	2014	Caprice	Body	Body Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
N	2014	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
N	2014	Caprice	Body	Passenger Presence Module	V	V																			V																																			
N	2014	Caprice	Body	Instrument Cluster	V	V																		V	V																																			
N	2014	Caprice	Body	Radio Controls	V																			V	V																																			
N	2014	Caprice	Body	HVAC Controls	V	V																		V	V																																			
N	2014	Caprice	Body	Headlamp Control Module	V	V																		V	V																							V											
N	2014	Caprice	Body	Trailer Interface Control Module	V	V																		V	V																																			
N	2014	Caprice	Body	Radio	V	V																		V	V																																			
N	2014	Caprice	Body	HVAC Control Module	V	V																		V	V																																			
N	2014	Caprice	Body	Parking Assist Control Module	V	V																		V	V																																			
N	2014	Caprice	Body	Frontview Camera Module	V	V																		V	V																																			
N	2014	Caprice	Body	Steering Column Lock Control Module	V	V																			V																																			
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V								V	V	V	V		V														
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V								V	V	V	V	V	V														
N	2015	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V								V	V	V	V									V														
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V													V														
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V	V														
N	2015	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module	V	V																		V	V								V	V	V	V									V														
N	2015	Caprice	Powertrain	Fuel Injector Control Module		V																		V	V																																			
N	2015	Caprice	Chassis	Electronic Brake Control Module	V	V																		V	V												V												V	V	V	V	V	V						
N	2015	Caprice	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
N	2015	Caprice	Chassis	Power Steering Control Module	V	V																			V																																			
N	2015	Caprice	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
N	2015	Caprice	Chassis	Suspension Control Module	V	V																			V																																			
N	2015	Caprice	Body	Body Control Module	V	V																		V	V																																			
N	2015	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
N	2015	Caprice	Body	Passenger Presence Module	V	V																			V																																			
N	2015	Caprice	Body	Instrument Cluster	V	V																		V	V																																			
N	2015	Caprice	Body	Head-Up Display Module	V																			V	V																																			
N	2015	Caprice	Body	Radio Controls	V																			V	V																																			
N	2015	Caprice	Body	HVAC Controls	V	V																		V	V																																			
N	2015	Caprice	Body	Headlamp Control Module	V	V																		V	V																							V											
N	2015	Caprice	Body	Trailer Interface Control Module	V	V																		V	V																																			
N	2015	Caprice	Body	Radio	V	V																		V	V																																			
N	2015	Caprice	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
N	2015	Caprice	Body	HVAC Control Module	V	V																		V	V																																			
N	2015	Caprice	Body	Right Side Object Detection Control Module	V																			V	V																																			
N	2015	Caprice	Body	Left Side Object Detection Control Module	V																			V	V																																			
N	2015	Caprice	Body	Parking Assist Control Module	V	V																		V	V																																			
N	2015	Caprice	Body	Frontview Camera Module	V	V																		V	V																																			
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V								V	V	V	V		V														
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V								V	V	V	V		V														
N	2016	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V								V	V	V	V									V														
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V													V														
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V	V														
N	2016	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module	V	V																		V	V								V	V	V	V									V														
N	2016	Caprice	Powertrain	Fuel Injector Control Module		V																		V	V																																			
N	2016	Caprice	Chassis	Electronic Brake Control Module	V	V																		V	V												V												V	V	V	V	V	V						
N	2016	Caprice	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
N	2016	Caprice	Chassis	Power Steering Control Module	V	V																			V																																			
N	2016	Caprice	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
N	2016	Caprice	Chassis	Suspension Control Module	V	V																		V	V																																			
N	2016	Caprice	Body	Body Control Module	V	V																		V	V																																			
N	2016	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
N	2016	Caprice	Body	Passenger Presence Module	V	V																			V																																			
N	2016	Caprice	Body	Instrument Cluster	V	V																		V	V																																			
N	2016	Caprice	Body	Head-Up Display Module	V																			V	V																																			
N	2016	Caprice	Body	Radio Controls	V																			V	V																																			
N	2016	Caprice	Body	HVAC Controls	V	V																		V	V																																			
N	2016	Caprice	Body	Trailer Interface Control Module	V	V																		V	V																																			
N	2016	Caprice	Body	Radio	V	V																		V	V																																			
N	2016	Caprice	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
N	2016	Caprice	Body	HVAC Control Module	V	V																		V	V																																			
N	2016	Caprice	Body	Seat Memory Control Module - Driver	V																																																							
N	2016	Caprice	Body	Right Side Object Detection Control Module	V																			V	V																																			
N	2016	Caprice	Body	Left Side Object Detection Control Module	V																			V	V																																			
N	2016	Caprice	Body	Parking Assist Control Module	V	V																		V	V																																			
N	2016	Caprice	Body	Frontview Camera Module	V	V																		V	V																																			
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission	V																			V	V																																			
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																			
P	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																												
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V												V																
P	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
P	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																												
P	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V											V																	
P	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission	V																			V	V																																			
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission	V																			V	V																																			
P	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
P	2010	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V								
P	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
P	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
P	2010	Cruze	Body	Body Control Module	V	V																		V	V																																			
P	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
P	2010	Cruze	Body	Passenger Presence Module	V	V																			V																																			
P	2010	Cruze	Body	Instrument Cluster	V	V																		V	V																																			
P	2010	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																			
P	2010	Cruze	Body	Radio	V	V																		V	V																																			
P	2010	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																			
P	2010	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																			
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
P	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)	V	V																		V	V																																			
P	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)	V	V																		V	V																																			
P	2010	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																			
P	2010	Cruze	Body	Parking Assist Control Module	V	V																		V	V																																			
P	2010	Cruze	Body	Steering Column Lock Control Module	V	V																			V																																			
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																												
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V																
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module	V	V																		V	V							V			V																									
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V		V	V																																			
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V		V	V																																			
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V		V	V						V	V																											
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V		V	V						V	V												V														
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission	V																		V	V																			V														
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission	V																		V	V																		V	V													
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V		V	V																																	
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V		V	V																																	
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V		V	V						V	V																											
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V		V	V						V	V												V														
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission	V																		V	V																			V														
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission	V																		V	V																		V	V													
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V		V	V					V		V																										
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																		V	V					V		V												V														
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module	V	V																	V	V							V			V																							
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission	V																		V	V																																	
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission	V																		V	V																																	
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																		
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V																										
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V												V														
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
P	2011	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																
P	2011	Cruze	Body	Body Control Module	V	V																		V	V																																
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																
P	2011	Cruze	Body	Passenger Presence Module	V	V																			V																																
P	2011	Cruze	Body	Instrument Cluster	V	V																		V	V																																
P	2011	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																
P	2011	Cruze	Body	Radio	V	V																		V	V																																
P	2011	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																
P	2011	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)	V	V																		V	V																																
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)	V	V																		V	V																																
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)	V	V																		V	V																																
P	2011	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																
P	2011	Cruze	Body	Parking Assist Control Module	V	V																		V	V																																
P	2011	Cruze	Body	Steering Column Lock Control Module	V	V																			V																																
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V														
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module	V	V																		V	V								V																							
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																	
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V		V	V																																		
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																											
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V														
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission	V																			V	V																					V													
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission	V																			V	V																				V	V													
P	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																		
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																		
P	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																		
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																		
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																											
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V														
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission	V																			V	V																					V													
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission	V																			V	V																				V	V													
P	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V																			V	V																																		
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V																			V	V																																		
P	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V					V		V																											
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																			V	V					V		V													V														
P	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module	V	V																		V	V							V		V																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission	V																			V	V																																		
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission	V																			V	V																																		
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V																												
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V														V														
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
P	2012	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
P	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
P	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
P	2012	Cruze	Body	Body Control Module Hatchback	V	V																		V	V																																		
P	2012	Cruze	Body	Body Control Module Sedan	V	V																		V	V																																		
P	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
P	2012	Cruze	Body	Passenger Presence Module	V	V																			V																																		
P	2012	Cruze	Body	Instrument Cluster	V	V																		V	V																																		
P	2012	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																		
P	2012	Cruze	Body	Radio	V	V																		V	V																																		
P	2012	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																		
P	2012	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																		
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
P	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)	V	V																		V	V																																		
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)	V	V																		V	V																																		
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)	V	V																		V	V																																		
P	2012	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																		
P	2012	Cruze	Body	Parking Assist Control Module	V	V																		V	V																																		
P	2012	Cruze	Body	Steering Column Lock Control Module	V	V																			V																																		
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V																					V														
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V																				V	V														
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Right Front Solenoid Valves	ABS Left Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V														
P	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V														
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																									
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
P	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																	
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																	
P	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																											
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V												V														
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V																																	
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V																			V														
P	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																	
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																	
P	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																	
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																	
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																											
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V												V														
P	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V																																	
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V																			V														
P	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V														
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																									
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
P	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V														
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																									
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
P	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V																											
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V														
P	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2013	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V						
P	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
P	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
P	2013	Cruze	Body	Body Control Module Hatchback	V	V																		V	V																																	
P	2013	Cruze	Body	Body Control Module Sedan	V	V																		V	V																																	
P	2013	Cruze	Body	Body Control Module Station Wagon	V	V																		V	V																																	
P	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
P	2013	Cruze	Body	Passenger Presence Module	V	V																			V																																	
P	2013	Cruze	Body	Instrument Cluster	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2013	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																			
P	2013	Cruze	Body	Radio	V	V																		V	V																																		
P	2013	Cruze	Body	Digital Radio Receiver Control Module	V	V																			V																																		
P	2013	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																		
P	2013	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																		
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																		
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
P	2013	Cruze	Body	Front Seat Heating Control Module	V	V																		V	V																																		
P	2013	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																		
P	2013	Cruze	Body	Right Side Object Detection Control Module	V																			V	V																																		
P	2013	Cruze	Body	Left Side Object Detection Control Module	V																			V	V																																		
P	2013	Cruze	Body	Parking Assist Control Module	V	V																		V	V																																		
P	2013	Cruze	Body	Steering Column Lock Control Module	V	V																			V																																		
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V													
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V													
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter	V	V																			V																																		
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																		
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																		
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V					V	V																												
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V					V	V														V													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V																																		
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V																				V													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter	V	V																			V																																		
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V								V										V	V							V																											
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V													
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																		
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																		
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																		
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																		
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																		
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																		
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V					V	V																												
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V					V	V														V													
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V																																	
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V																		V															
P	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V				V		V																											
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V				V		V												V															
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump	V	V																		V	V						V		V																									
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V						V																											
P	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V				V		V																											
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V				V		V												V															
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump	V	V																		V	V						V		V																									
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V						V																											
P	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V																											
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V												V															
P	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module	V	V	V	V		V	V	V		V	V	V	V		V	V	V			V	V						V	V	V																									
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump	V	V																		V	V						V		V																									
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V						V																											
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module		V								V										V	V																																	
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module	V	V																		V	V										V		V																					
P	2014	Cruze	Powertrain	Fuel Injector Control Module		V																		V	V																																	
P	2014	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V						
P	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
P	2014	Cruze	Chassis	Power Steering Control Module	V	V																			V																																	
P	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
P	2014	Cruze	Body	Body Control Module Hatchback	V	V																		V	V																																	
P	2014	Cruze	Body	Body Control Module Sedan	V	V																		V	V																																	
P	2014	Cruze	Body	Body Control Module Station Wagon	V	V																		V	V																																	
P	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
P	2014	Cruze	Body	Passenger Presence Module	V	V																			V																																	
P	2014	Cruze	Body	Instrument Cluster	V	V																		V	V																																	
P	2014	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																	
P	2014	Cruze	Body	Radio	V	V																		V	V																																	
P	2014	Cruze	Body	Digital Radio Receiver Control Module	V	V																			V																																	
P	2014	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																	
P	2014	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																	
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
P	2014	Cruze	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																	
P	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																	
P	2014	Cruze	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																	
P	2014	Cruze	Body	Front Seat Heating Control Module	V	V																		V	V																																	
P	2014	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																	
P	2014	Cruze	Body	Right Side Object Detection Control Module	V																			V	V																																	
P	2014	Cruze	Body	Left Side Object Detection Control Module	V																			V	V																																	
P	2014	Cruze	Body	Parking Assist Control Module	V	V																		V	V																																	
P	2014	Cruze	Body	Steering Column Lock Control Module	V	V																			V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																												
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V															
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																												
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V															
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter	V	V																			V																																		
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																										
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																												
P	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V															
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter	V	V																			V																																		
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																		
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																		
P	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V															
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V																																		
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V																				V															
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter	V	V																			V																																		
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																												
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V															
P	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission	V																			V	V																																		
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission	V																			V	V																																		
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V	V	V	V		V		V	V	V		V	V	V	V	V	V	V		V	V																																		
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V	V	V			V		V	V	V		V	V	V	V	V	V	V		V	V																																		
P	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																		
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																		
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																		
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																		
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																												
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V															
P	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V																																		
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V																				V															
P	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V															
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter	V	V																			V																																		
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																												
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V															

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter	V	V																			V																																			
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
P	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V																											
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V													
P	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module	V	V	V	V		V	V	V		V	V	V	V		V	V	V			V	V						V	V	V																									
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter	V	V																			V																																	
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump	V	V																		V	V							V		V																									
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module		V								V										V	V																																		
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module	V	V																		V	V										V		V																						
P	2015	Cruze	Powertrain	Fuel Injector Control Module		V																		V	V																																		
P	2015	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
P	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
P	2015	Cruze	Chassis	Power Steering Control Module	V	V																			V																																		
P	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
P	2015	Cruze	Body	Body Control Module Hatchback	V	V																		V	V																																		
P	2015	Cruze	Body	Body Control Module Sedan	V	V																		V	V																																		
P	2015	Cruze	Body	Body Control Module Station Wagon	V	V																		V	V																																		
P	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
P	2015	Cruze	Body	Passenger Presence Module	V	V																			V																																		
P	2015	Cruze	Body	Instrument Cluster	V	V																		V	V																																		
P	2015	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																		
P	2015	Cruze	Body	Radio	V	V																		V	V																																		
P	2015	Cruze	Body	Digital Radio Receiver Control Module	V	V																			V																																		
P	2015	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																		
P	2015	Cruze	Body	Mobile Telephone Control Module	V	V																		V	V																																		
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
P	2015	Cruze	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
P	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																		
P	2015	Cruze	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
P	2015	Cruze	Body	Front Seat Heating Control Module	V	V																		V	V																																		
P	2015	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																		
P	2015	Cruze	Body	Right Side Object Detection Control Module	V																			V	V																																		
P	2015	Cruze	Body	Left Side Object Detection Control Module	V																			V	V																																		
P	2015	Cruze	Body	Parking Assist Control Module	V	V																			V																																		
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V													
P	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V													
P	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V																			V	V																																		
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V																			V	V																																		
P	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V					V	V																											
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V					V	V													V													
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V																			V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V																		V	V																			V															
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission	V																		V	V																																	
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission	V																		V	V																																	
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V																		V	V																																	
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V																		V	V																																	
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V						V	V																										
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V	V						V	V												V														
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V																		V	V																																	
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V																		V	V									V																								
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V																										
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V												V														
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V																										
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V												V														
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																		V	V			V			V																										
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																		V	V			V			V													V														
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
P	2016	Cruze	Powertrain	Fuel Injector Control Module		V																	V	V																																	
P	2016	Cruze	Powertrain	Chassis Control Module	V	V									V								V	V							V																										
P	2016	Cruze	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V							
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																															V	V
P	2016	Cruze	Chassis	Power Steering Control Module	V	V																		V																																
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																			V																																
P	2016	Cruze	Body	Body Control Module Hatchback	V	V																	V	V																																
P	2016	Cruze	Body	Body Control Module Sedan	V	V																	V	V																																
P	2016	Cruze	Body	Body Control Module Station Wagon	V	V																	V	V																																
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																
P	2016	Cruze	Body	Passenger Presence Module	V	V																		V																																
P	2016	Cruze	Body	Instrument Cluster	V	V																	V	V																																
P	2016	Cruze	Body	Trailer Interface Control Module	V	V																	V	V																																
P	2016	Cruze	Body	Radio Other	V	V																	V	V																																
P	2016	Cruze	Body	Radio (UF7)	V	V																	V	V																																
P	2016	Cruze	Body	Multimedia Player Interface Module	V	V																		V																																
P	2016	Cruze	Body	Mobile Telephone Control Module	V	V																	V	V																																
P	2016	Cruze	Body	Telematics Communication Interface Control Module	V	V																	V	V																																
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																	V	V																																
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)	V	V																	V	V																																
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)	V	V																	V	V																																
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)	V	V																	V	V																																
P	2016	Cruze	Body	Front Seat Heating Control Module	V	V																	V	V																																
P	2016	Cruze	Body	Keyless Entry Control Module	V	V																	V	V																																
P	2016	Cruze	Body	Right Side Object Detection Control Module	V																		V	V																																
P	2016	Cruze	Body	Left Side Object Detection Control Module	V																		V	V																																
P	2016	Cruze	Body	Parking Assist Control Module	V	V																	V	V																																
P	2016	Cruze	Body	Steering Column Lock Control Module	V	V																		V																																

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2011	Volt	Powertrain	Engine Control Module	V																			V	V	V	V	V	V	V	V	V																													
R	2011	Volt	Powertrain	Trasmission Control Module	V	V																		V	V										V		V	V								V														
R	2011	Volt	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																										
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module	V	V	V																	V	V										V																								
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module 2	V	V									V									V	V																																		
R	2011	Volt	Powertrain	Drive Motor Control Module 1		V																			V																																		
R	2011	Volt	Powertrain	Drive Motor Control Module 2		V																			V																																		
R	2011	Volt	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																		
R	2011	Volt	Chassis	Electronic Brake Control Module	V	V																		V	V																												V						
R	2011	Volt	Chassis	Parking Brake Control Module	V	V																			V																							V						V	V	V	V		
R	2011	Volt	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
R	2011	Volt	Chassis	Power Steering Control Module	V	V																			V																																		
R	2011	Volt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
R	2011	Volt	Body	Body Control Module	V	V																		V	V																																		
R	2011	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
R	2011	Volt	Body	Passenger Presence Module	V	V																			V																																		
R	2011	Volt	Body	Instrument Cluster	V	V																		V	V																																		
R	2011	Volt	Body	Radio	V	V																		V	V																																		
R	2011	Volt	Body	Digital Radio Receiver Control Module	V	V																			V																																		
R	2011	Volt	Body	Mobile Telephone Control Module	V	V																		V	V																																		
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
R	2011	Volt	Body	Remote Heater and Air Conditioning Control Module	V	V																		V	V																																		
R	2011	Volt	Body	Electric A/C Compressor Control Module																					V																																		
R	2011	Volt	Body	Coolant Heater Control Module	V																				V																																		
R	2011	Volt	Body	Keyless Entry Control Module	V																				V																																		
R	2011	Volt	Body	Parking Assist Control Module	V	V																		V	V																																		
R	2011	Volt	Body	Steering Column Lock Control Module	V	V																			V																																		
R	2011	Volt	Body	Battery Charger Control Module		V																			V																																		
R	2011	Volt	Body	Battery Energy Control Module		V																			V																																		
R	2012	Volt	Powertrain	Engine Control Module	V																			V	V	V	V	V	V	V	V	V																												
R	2012	Volt	Powertrain	Trasmission Control Module	V	V																		V	V										V		V	V								V													
R	2012	Volt	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																									
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module	V	V	V																	V	V										V																							
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module 2	V	V									V									V	V																																		
R	2012	Volt	Powertrain	Drive Motor Control Module 1		V																			V																																		
R	2012	Volt	Powertrain	Drive Motor Control Module 2		V																			V																																		
R	2012	Volt	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																		
R	2012	Volt	Chassis	Electronic Brake Control Module	V	V																		V	V																												V						
R	2012	Volt	Chassis	Parking Brake Control Module	V	V																			V																							V						V	V	V	V		
R	2012	Volt	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
R	2012	Volt	Chassis	Power Steering Control Module	V	V																			V																																		
R	2012	Volt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
R	2012	Volt	Body	Body Control Module	V	V																		V	V																																		
R	2012	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
R	2012	Volt	Body	Passenger Presence Module	V	V																			V																																		
R	2012	Volt	Body	Instrument Cluster	V	V																		V	V																																		
R	2012	Volt	Body	Radio	V	V																		V	V																																		
R	2012	Volt	Body	Digital Radio Receiver Control Module	V	V																			V																																		
R	2012	Volt	Body	Mobile Telephone Control Module	V	V																		V	V																																		
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																				
R	2012	Volt	Body	Remote Heater and Air Conditioning Control Module	V	V																		V	V																																			
R	2012	Volt	Body	Electric A/C Compressor Control Module																					V																																				
R	2012	Volt	Body	Coolant Heater Control Module	V																				V																																				
R	2012	Volt	Body	Keyless Entry Control Module	V	V																		V	V																																				
R	2012	Volt	Body	Parking Assist Control Module	V	V																		V	V																																				
R	2012	Volt	Body	Steering Column Lock Control Module	V	V																			V																																				
R	2012	Volt	Body	Battery Charger Control Module		V																			V																																				
R	2012	Volt	Body	Battery Energy Control Module		V																			V																																				
R	2013	Volt	Powertrain	Engine Control Module	V																			V	V	V	V	V	V	V	V	V																														
R	2013	Volt	Powertrain	Trasmission Control Module	V	V																		V	V										V		V	V								V														
R	2013	Volt	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																										
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module	V	V	V																	V	V										V																								
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module 2	V	V									V									V	V																																			
R	2013	Volt	Powertrain	Drive Motor Control Module 1		V																			V																																			
R	2013	Volt	Powertrain	Drive Motor Control Module 2		V																			V																																			
R	2013	Volt	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																			
R	2013	Volt	Chassis	Electronic Brake Control Module	V	V																		V	V																													V						
R	2013	Volt	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
R	2013	Volt	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
R	2013	Volt	Chassis	Power Steering Control Module	V	V																			V																																			
R	2013	Volt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
R	2013	Volt	Body	Body Control Module	V	V																		V	V																																			
R	2013	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
R	2013	Volt	Body	Passenger Presence Module	V	V																			V																																			
R	2013	Volt	Body	Instrument Cluster	V	V																		V	V																																			
R	2013	Volt	Body	Radio	V	V																		V	V																																			
R	2013	Volt	Body	Digital Radio Receiver Control Module	V	V																			V																																			
R	2013	Volt	Body	Multimedia Player Interface Module	V	V																			V																																			
R	2013	Volt	Body	Mobile Telephone Control Module	V	V																		V	V																																			
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
R	2013	Volt	Body	HVAC Control Module	V	V																		V	V																																			
R	2013	Volt	Body	Electric A/C Compressor Control Module																					V																																			
R	2013	Volt	Body	Coolant Heater Control Module	V																				V																																			
R	2013	Volt	Body	Front Seat Heating Control Module	V	V																		V	V																																			
R	2013	Volt	Body	Keyless Entry Control Module	V	V																		V	V																																			
R	2013	Volt	Body	Parking Assist Control Module	V	V																		V	V																																			
R	2013	Volt	Body	Frontview Camera Module	V	V																		V	V																																			
R	2013	Volt	Body	Steering Column Lock Control Module	V	V																			V																																			
R	2013	Volt	Body	Battery Charger Control Module		V																			V																																			
R	2013	Volt	Body	Battery Energy Control Module		V																			V																																			
R	2014	Volt	Powertrain	Engine Control Module	V																			V	V	V	V	V	V	V	V	V																														
R	2014	Volt	Powertrain	Trasmission Control Module	V	V																		V	V										V		V	V								V														
R	2014	Volt	Powertrain	Chassis Control Module	V	V																		V	V							V		V																										
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module	V	V	V																	V	V										V																								
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module 2	V	V									V									V	V																																			
R	2014	Volt	Powertrain	Drive Motor Control Module 1		V																			V																																			
R	2014	Volt	Powertrain	Drive Motor Control Module 2		V																			V																																			
R	2014	Volt	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																			
R	2014	Volt	Chassis	Electronic Brake Control Module	V	V																		V	V																													V						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Right Front Solenoid Valves	ABS Left Front Solenoid Valves	ABS Right Rear Solenoid Valves	ABS Left Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2014	Volt	Chassis	Parking Brake Control Module	V	V																			V																						V						V	V	V	V		
R	2014	Volt	Chassis	Power Steering Control Module	V	V																			V																																	
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
R	2014	Volt	Body	Body Control Module	V	V																		V	V																																	
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
R	2014	Volt	Body	Passenger Presence Module	V	V																			V																																	
R	2014	Volt	Body	Instrument Cluster	V	V																		V	V																																	
R	2014	Volt	Body	Radio	V	V																		V	V																																	
R	2014	Volt	Body	Digital Radio Receiver Control Module	V	V																			V																																	
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
R	2014	Volt	Body	HVAC Control Module	V	V																		V	V																																	
R	2014	Volt	Body	Electric A/C Compressor Control Module																					V																																	
R	2014	Volt	Body	Coolant Heater Control Module	V																				V																																	
R	2014	Volt	Body	Front Seat Heating Control Module	V	V																		V	V																																	
R	2014	Volt	Body	Keyless Entry Control Module	V	V																		V	V																																	
R	2014	Volt	Body	Parking Assist Control Module	V	V																		V	V																																	
R	2014	Volt	Body	Frontview Camera Module	V	V																		V	V																																	
R	2014	Volt	Body	Steering Column Lock Control Module	V	V																			V																																	
R	2014	Volt	Body	Battery Charger Control Module		V																			V																																	
R	2014	Volt	Body	Battery Energy Control Module		V																			V																																	
R	2015	Volt	Powertrain	Engine Control Module	V																			V	V	V	V	V	V	V	V	V																											
R	2015	Volt	Powertrain	Trasmission Control Module	V	V																		V	V										V		V	V									V										
R	2015	Volt	Powertrain	Chassis Control Module	V	V																		V	V							V		V																							
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module	V	V	V																	V	V										V																						
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2	V	V								V										V	V																																	
R	2015	Volt	Powertrain	Drive Motor Control Module 1		V																			V																																	
R	2015	Volt	Powertrain	Drive Motor Control Module 2		V																			V																																	
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																	
R	2015	Volt	Chassis	Electronic Brake Control Module	V	V																		V	V																														V				
R	2015	Volt	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
R	2015	Volt	Chassis	Power Steering Control Module	V	V																			V																																	
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
R	2015	Volt	Body	Body Control Module	V	V																		V	V																																	
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
R	2015	Volt	Body	Passenger Presence Module	V	V																			V																																	
R	2015	Volt	Body	Instrument Cluster	V	V																		V	V																																	
R	2015	Volt	Body	Radio	V	V																		V	V																																	
R	2015	Volt	Body	Digital Radio Receiver Control Module	V	V																			V																																	
R	2015	Volt	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
R	2015	Volt	Body	HVAC Control Module	V	V																		V	V																																	
R	2015	Volt	Body	Electric A/C Compressor Control Module																					V																																	
R	2015	Volt	Body	Coolant Heater Control Module	V																				V																																	
R	2015	Volt	Body	Front Seat Heating Control Module	V	V																		V	V																																	
R	2015	Volt	Body	Keyless Entry Control Module	V	V																		V	V																																	
R	2015	Volt	Body	Parking Assist Control Module	V	V																		V	V																																	
R	2015	Volt	Body	Frontview Camera Module	V	V																		V	V																																	
R	2015	Volt	Body	Steering Column Lock Control Module	V	V																			V																																	
R	2015	Volt	Body	Battery Charger Control Module		V																			V																																	
R	2015	Volt	Body	Battery Energy Control Module		V																			V																																	
R	2016	Volt	Powertrain	Engine Control Module	V																			V	V			V	V	V	V	V																											

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module	V	V	V																	V	V										V																									
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module 2	V	V									V									V	V																																			
R	2016	Volt	Powertrain	Drive Motor Control Module 1		V																			V																																			
R	2016	Volt	Powertrain	Drive Motor Control Module 2		V																			V																																			
R	2016	Volt	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V				V		
R	2016	Volt	Chassis	Brake Booster Control Module	V	V																			V																																			
R	2016	Volt	Chassis	Power Steering Control Module	V	V																			V																																			
R	2016	Volt	Body	Body Control Module	V	V																		V	V																																			
R	2016	Volt	Body	Pedestrian Alert Sound Control Module	V	V																			V																																			
R	2016	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
R	2016	Volt	Body	Passenger Presence Module	V	V																			V																																			
R	2016	Volt	Body	Instrument Cluster	V	V																		V	V																																			
R	2016	Volt	Body	Radio Controls	V																				V																																			
R	2016	Volt	Body	HVAC Controls	V																			V	V																																			
R	2016	Volt	Body	Radio	V	V																		V	V																																			
R	2016	Volt	Body	Amplifier	V	V																			V																																			
R	2016	Volt	Body	Human Machine Interface Control Module	V	V																		V	V																							V												
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
R	2016	Volt	Body	HVAC Control Module	V	V																		V	V																																			
R	2016	Volt	Body	Electric A/C Compressor Control Module																					V																																			
R	2016	Volt	Body	Keyless Entry Control Module	V	V																		V	V																																			
R	2016	Volt	Body	Right Side Object Detection Control Module	V																			V	V																																			
R	2016	Volt	Body	Left Side Object Detection Control Module	V																			V	V																																			
R	2016	Volt	Body	Parking Assist Control Module	V																			V	V																																			
R	2016	Volt	Body	Frontview Camera Module	V	V																		V	V																																			
R	2016	Volt	Body	Steering Column Lock Control Module	V	V																			V																																			
R	2016	Volt	Body	Battery Energy Control Module		V																			V																																			
R	2016	Volt	Body	Long Range Radar Sensor Module	V	V																			V																																			
S	2004	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module	V	V																		V	V																					V														
S	2004	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module	V	V																		V	V																					V														
S	2004	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V					V			V																					V														
S	2004	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module	V	V	V						V			V					V			V																					V														
S	2004	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V					V			V																					V														
S	2004	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V	V						V			V					V			V																					V														
S	2004	Aveo	Powertrain	Transmission Control Module	V	V																		V	V																																			
S	2004	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
S	2004	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
S	2004	Aveo	Body	Supplemental Inflatable Restraint	V																				V																																			
S	2004	Aveo	Body	Remote Function Actuation		V																																																					
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module	V	V																		V	V																					V														
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Transmission Control Module	V	V																		V	V																																			
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module	V	V																		V	V																					V														
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module	V	V																		V	V																																			
S	2005	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module	V	V																		V	V																					V														
S	2005	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V					V			V																					V														
S	2005	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module	V	V	V						V			V					V			V																					V														
S	2005	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V					V			V																					V														
S	2005	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V	V						V			V					V			V																					V														
S	2005	Aveo	Powertrain	Transmission Control Module	V	V																		V	V																																			
S	2005	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2005	Aveo	Body	Supplemental Inflatable Restraint	V																				V																																					
S	2005	Aveo	Body	Remote Function Actuation		V																																																								
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module	V	V																		V	V																					V																
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module	V	V																		V	V																																					
S	2006	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module	V	V											V							V	V																					V																
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V					V			V																					V																
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India	V	V	V						V			V					V			V																					V																
S	2006	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module	V	V	V						V			V					V			V																					V																
S	2006	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V					V			V																					V																
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V	V						V			V					V	V		V																					V																
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																					V																
S	2006	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																					
S	2006	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
S	2006	Aveo	Body	Supplemental Inflatable Restraint	V	V																		V	V																																					
S	2006	Aveo	Body	Remote Function Actuation		V																																																								
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module	V	V																		V	V																					V																
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module	V	V																		V	V																																					
S	2007	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module	V	V											V							V	V																					V																
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V	V				V			V																					V																
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India	V	V	V						V			V					V			V																					V																
S	2007	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module	V	V	V						V			V	V				V			V																					V																
S	2007	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V	V				V			V																					V																
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V	V						V			V					V	V		V																					V																
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																					V																
S	2007	Aveo	Powertrain	Transmission Control Module 4 Speed	V	V																		V	V																																					
S	2007	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																					
S	2007	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
S	2007	Aveo	Body	Supplemental Inflatable Restraint	V	V																		V	V																																					
S	2007	Aveo	Body	Remote Function Actuation		V																																																								
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module	V	V																		V	V																					V																
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module	V	V																		V	V																																					
S	2008	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module	V	V											V							V	V																																					
S	2008	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module	V	V											V							V	V																					V																
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V	V				V			V																					V																
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India	V	V	V						V			V					V			V																					V																
S	2008	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module	V	V	V						V			V	V				V	V		V	V							V													V																
S	2008	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V	V				V			V																					V																
S	2008	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																					V																
S	2008	Aveo	Powertrain	Transmission Control Module	V	V																		V	V																																					
S	2008	Aveo	Powertrain	Transmission Control Module	V	V																		V	V										V	V																									
S	2008	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
S	2008	Aveo	Chassis	Tire Pressure Monitor	V	V																			V																																					
S	2008	Aveo	Body	Supplemental Inflatable Restraint	V	V																		V	V																																					
S	2008	Aveo	Body	Remote Function Actuation		V																																																								
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module	V	V																		V	V																					V																
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module	V	V																		V	V																																					
S	2009	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module	V	V											V							V	V																																					
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V	V				V			V																					V																
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India	V	V	V						V			V					V			V																					V																
S	2009	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module	V	V	V						V			V	V				V	V		V	V							V													V																
S	2009	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V	V				V			V																					V																

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2009	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																			V															
S	2009	Aveo	Powertrain	Transmission Control Module	V	V																		V	V																																		
S	2009	Aveo	Powertrain	Transmission Control Module	V	V																		V	V									V	V																								
S	2009	Aveo	Powertrain	Other Auto Transmission System	V	V																		V	V																																		
S	2009	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
S	2009	Aveo	Chassis	Tire Pressure Monitor	V	V																			V																																		
S	2009	Aveo	Body	Supplemental Inflatable Restraint	V	V																		V	V																																		
S	2009	Aveo	Body	Remote Function Actuation		V																																																					
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module	V	V																		V	V																				V														
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module	V	V																		V	V																																		
S	2010	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module	V	V											V							V	V																																		
S	2010	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V	V				V			V																				V														
S	2010	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module	V	V	V						V			V	V				V	V		V	V							V												V														
S	2010	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V	V				V			V																				V														
S	2010	Aveo	Powertrain	(6)1.6L L4 LXT Engine Control Module	V	V	V						V			V	V				V			V																				V														
S	2010	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																			V														
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																		
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V									V	V																								
S	2010	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
S	2010	Aveo	Chassis	Tire Pressure Monitor	V	V																			V																																		
S	2010	Aveo	Body	Supplemental Inflatable Restraint	V	V																		V	V																																		
S	2010	Aveo	Body	Remote Function Actuation		V																																																				
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
S	2010	Sail	Powertrain	1.4L LCU Engine Control Module	V	V	V			V			V			V	V	V			V			V	V			V				V																										
S	2010	Sail	Powertrain	Transmission Control Module	V																			V	V										V																								
S	2010	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																													V					
S	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module	V	V																		V	V																				V														
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module	V	V																		V	V																																		
S	2011	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module	V	V											V							V	V																																		
S	2011	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V	V				V			V																				V														
S	2011	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module	V	V	V						V			V	V				V	V		V	V							V												V														
S	2011	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V	V				V			V																				V														
S	2011	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																			V														
S	2011	Aveo	Powertrain	(G)1.6L L4 LXV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																			V														
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																		
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V									V	V																								
S	2011	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
S	2011	Aveo	Chassis	Tire Pressure Monitor	V	V																			V																																		
S	2011	Aveo	Body	Supplemental Inflatable Restraint	V	V																		V	V																																		
S	2011	Aveo	Body	Remote Function Actuation		V																																																				
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
S	2011	Sail	Powertrain	1.4L LCU Engine Control Module	V	V	V			V			V			V	V	V			V			V	V			V				V																										
S	2011	Sail	Powertrain	Transmission Control Module	V																			V	V										V																								
S	2011	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																													V					
S	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
S	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module	V	V											V							V	V																																		
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V												V														
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V											V	V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
S	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																		
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																		
S	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
S	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V	V				V			V																						V													
S	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module	V	V	V						V			V	V				V	V		V	V							V														V													
S	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V	V				V			V																						V													
S	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module	V	V	V						V			V	V				V			V																						V													
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
S	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V													
S	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
S	2012	Aveo	Powertrain	Fuel Pump Control Module	V	V																		V	V							V			V																									
S	2012	Aveo	Powertrain	Fuel Injector Control Module		V																		V	V																																		
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																		
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V									V	V																									
S	2012	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
S	2012	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
S	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
S	2012	Aveo	Chassis	Electric Power Steering Control Module	V	V																			V																																		
S	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
S	2012	Aveo	Chassis	Tire Pressure Monitor	V	V																			V																																		
S	2012	Aveo	Body	Body Control Module Hatchback	V	V																		V	V																																		
S	2012	Aveo	Body	Body Control Module Sedan	V	V																		V	V																																		
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
S	2012	Aveo	Body	Passenger Presence Module	V	V																			V																																		
S	2012	Aveo	Body	Instrument Cluster	V	V																		V	V																																		
S	2012	Aveo	Body	Radio	V	V																		V	V																																		
S	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module	V	V																		V	V																																		
S	2012	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
S	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
S	2012	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
S	2012	Aveo	Body	Front Seat Heating Control Module	V	V																		V	V																																		
S	2012	Aveo	Body	Remote Function Actuation		V																																																				
S	2012	Aveo	Body	Parking Assist Control Module	V	V																			V																																		
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module	V	V																		V	V																						V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module	V	V																		V	V																																				
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																			
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																			
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																			
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																			
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																												
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																												
S	2012	Sail	Powertrain	Transmission Control Module	V																			V	V										V																									
S	2012	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																													V					
S	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
S	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module	V	V											V							V	V																																			
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																			
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																			
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
S	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V	V				V			V																					V													
S	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module	V	V	V						V			V	V				V	V		V								V													V													
S	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V	V				V			V																					V													
S	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module	V	V	V						V			V	V				V			V																					V													
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
S	2013	Aveo	Powertrain	Fuel Injector Control Module		V																		V	V																																			
S	2013	Aveo	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																									
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																			
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V										V	V																							
S	2013	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V					
S	2013	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
S	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
S	2013	Aveo	Chassis	Electric Power Steering Control Module	V	V																			V																																			
S	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
S	2013	Aveo	Body	Body Control Module Hatchback	V	V																		V	V																																			
S	2013	Aveo	Body	Body Control Module Sedan	V	V																		V	V																																			
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
S	2013	Aveo	Body	Passenger Presence Module	V	V																			V																																			
S	2013	Aveo	Body	Instrument Cluster	V	V																		V	V																																			
S	2013	Aveo	Body	Radio	V	V																		V	V																																			
S	2013	Aveo	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2013	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																				
S	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
S	2013	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
S	2013	Aveo	Body	Front Seat Heating Control Module	V	V																		V	V																																			
S	2013	Aveo	Body	Remote Function Actuation		V																																																					
S	2013	Aveo	Body	Parking Assist Control Module	V	V																			V																																		
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																										
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																										
S	2013	Sail	Powertrain	Transmission Control Module	V																			V	V										V																								
S	2013	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					
S	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
S	2014	Aveo	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V					V		V	V																																		
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																		
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																		
S	2014	Aveo	Powertrain	1.4L L95 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
S	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module	V	V																		V	V										V	V	V																					
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission	V																			V	V				V	V		V														V												
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission	V																			V	V				V	V		V														V												
S	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module	V	V																		V	V										V	V	V																					
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
S	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
S	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module	V	V																		V	V										V	V	V																					
S	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
S	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V										V	V	V																					
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2014	Aveo	Powertrain	1.6L LED Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V														
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
S	2014	Aveo	Powertrain	Chassis Control Module	V	V																	V	V							V		V																									
S	2014	Aveo	Powertrain	Fuel Injector Control Module		V																	V	V																																		
S	2014	Aveo	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V					
S	2014	Aveo	Chassis	Electronic Brake Control Module	V	V																	V	V																																	
S	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V
S	2014	Aveo	Chassis	Power Steering Control Module	V	V																		V																																	
S	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
S	2014	Aveo	Body	Body Control Module Hatchback	V	V																	V	V																																	
S	2014	Aveo	Body	Body Control Module Sedan	V	V																	V	V																																	
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																	
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V					V	V																																	
S	2014	Aveo	Body	Instrument Cluster	V	V																	V	V																																	
S	2014	Aveo	Body	Radio	V	V																	V	V																																	
S	2014	Aveo	Body	Telematics Communication Interface Control Module	V	V																	V	V																																	
S	2014	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																	V	V																																	
S	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																	V	V																																	
S	2014	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																	V	V																																	
S	2014	Aveo	Body	Front Seat Heating Control Module	V	V																	V	V																																	
S	2014	Aveo	Body	Keyless Entry Control Module		V																																																			
S	2014	Aveo	Body	Parking Assist Control Module	V	V																		V																																	
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																								
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																								
S	2014	Sail	Powertrain	Transmission Control Module	V																			V	V										V																					
S	2014	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																												V				
S	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																
S	2015	Aveo	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V					V		V	V																																
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																
S	2015	Aveo	Powertrain	1.4L L95 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																								
S	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module	V	V																		V	V										V	V	V																				
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission	V																			V	V				V	V		V														V												
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission	V																			V	V				V	V		V														V												
S	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module	V	V																		V	V										V	V	V																				
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V												
S	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																	
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
S	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
S	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module	V	V																		V	V										V	V	V																						
S	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
S	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V										V	V	V																						
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2015	Aveo	Powertrain	1.6L LED Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
S	2015	Aveo	Powertrain	Chassis Control Module	V	V																		V	V							V		V																									
S	2015	Aveo	Powertrain	Fuel Injector Control Module		V																		V	V																																			
S	2015	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V						
S	2015	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
S	2015	Aveo	Chassis	Power Steering Control Module	V	V																			V																																		
S	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
S	2015	Aveo	Body	Body Control Module Hatchback	V	V																		V	V																																		
S	2015	Aveo	Body	Body Control Module Sedan	V	V																		V	V																																		
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																		
S	2015	Aveo	Body	Instrument Cluster	V	V																		V	V																																		
S	2015	Aveo	Body	Radio	V	V																		V	V																																		
S	2015	Aveo	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
S	2015	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
S	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
S	2015	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
S	2015	Aveo	Body	Front Seat Heating Control Module	V	V																		V	V																																		
S	2015	Aveo	Body	Keyless Entry Control Module		V																																																					
S	2015	Aveo	Body	Parking Assist Control Module	V	V																			V																																		
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																											
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																											
S	2015	Sail	Powertrain	Transmission Control Module	V																			V	V										V																								
S	2015	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																													V					
S	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V														
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																		
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																		
S	2016	Aveo	Powertrain	1.4L L95 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
S	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module	V	V																		V	V									V	V	V																						
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
S	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																										
S	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module	V	V																		V	V										V	V	V																					
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2016	Aveo	Powertrain	1.6L LED Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
S	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
S	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																										
S	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V										V	V	V																					
S	2016	Aveo	Powertrain	Chassis Control Module	V	V																		V	V							V		V																								
S	2016	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																	
S	2016	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V					
S	2016	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V					
S	2016	Aveo	Chassis	Power Steering Control Module	V	V																			V																																
S	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																				V																																
S	2016	Aveo	Body	Body Control Module Hatchback	V	V																		V	V																																	
S	2016	Aveo	Body	Body Control Module Sedan	V	V																		V	V																																	
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																	
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
S	2016	Aveo	Body	Instrument Cluster	V	V																		V	V																																	
S	2016	Aveo	Body	Radio	V	V																		V	V																																	
S	2016	Aveo	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
S	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																	
S	2016	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																	
S	2016	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																	
S	2016	Aveo	Body	Front Seat Heating Control Module	V	V																		V	V																																	
S	2016	Aveo	Body	Parking Assist Control Module	V																			V	V																																	
S	2016	Aveo	Body	Keyless Entry Control Module		V																																																			
S	2016	Aveo	Body	Frontview Camera Module	V	V																		V	V																																	
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																	
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2016	Sail	Powertrain	1.3L LDV Engine Control Module	V																			V	V																																					
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																												
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																												
S	2016	Sail	Powertrain	Transmission Control Module	V																			V	V										V																									
S	2016	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																													V						
S	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
T	2004	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module	V	V																		V	V																					V													
T	2004	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V					V			V																					V													
T	2004	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module	V	V	V						V			V					V			V																					V													
T	2004	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V					V			V																					V													
T	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V	V						V			V					V			V																					V													
T	2004	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																		
T	2004	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
T	2004	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
T	2004	ALL	Body	Supplemental Inflatable Restraint	V																				V																																		
T	2004	ALL	Body	Remote Function Actuation		V																																																					
T	2005	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module	V	V																		V	V																					V													
T	2005	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V					V			V																					V													
T	2005	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module	V	V	V						V			V					V			V																					V													
T	2005	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V					V			V																					V													
T	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V	V						V			V					V			V																					V													
T	2005	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																		
T	2005	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
T	2005	ALL	Body	Supplemental Inflatable Restraint	V																				V																																		
T	2005	ALL	Body	Remote Function Actuation		V																																																				
T	2006	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module	V	V											V							V	V																					V													
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V					V			V																					V													
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India	V	V	V						V			V					V			V																					V													
T	2006	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module	V	V	V						V			V					V			V																					V													
T	2006	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V					V			V																					V													
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V	V						V			V					V	V		V																					V													
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																					V													
T	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																		
T	2006	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
T	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																		
T	2006	ALL	Body	Remote Function Actuation		V																																																				
T	2007	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module	V	V											V							V	V																					V													
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V	V				V			V																					V													
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India	V	V	V						V			V					V			V																					V													
T	2007	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module	V	V	V						V			V	V				V			V																					V													
T	2007	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V	V				V			V																					V													
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V	V						V			V					V	V		V																					V													
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																					V													
T	2007	ALL	Powertrain	Transmission Control Module 4 Speed	V	V																		V	V																																		
T	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																		
T	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
T	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																		
T	2007	ALL	Body	Remote Function Actuation		V																																																				
T	2008	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module	V	V											V							V	V																																		
T	2008	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module	V	V											V							V	V																					V													
T	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India	V	V	V						V			V					V			V																					V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2008	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module	V	V	V						V			V	V				V	V		V	V							V													V														
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V	V						V			V					V	V		V																					V														
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India	V	V	V						V			V					V			V																					V														
T	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module	V	V	V						V			V					V	V		V																					V														
T	2008	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																		
T	2008	ALL	Powertrain	Transmission Control Module	V	V																		V	V									V	V																								
T	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
T	2008	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																		
T	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																		
T	2008	ALL	Body	Remote Function Actuation		V																																																					
T	2008	ALL	Body	Passenger Presence System	V	V																			V																																		
T	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India	V	V	V						V			V					V			V																					V														
T	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module	V	V	V						V			V	V				V			V																					V														
T	2009	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																					V														
T	2009	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																		
T	2009	ALL	Powertrain	Transmission Control Module	V	V																		V	V										V	V																							
T	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
T	2009	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																		
T	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																		
T	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
T	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
T	2009	ALL	Body	Passenger Presence System	V	V																			V																																		
T	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																		
T	2009	ALL	Body	Radio	V																				V																																		
T	2009	ALL	Body	Remote Function Actuation		V																																																					
T	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module	V	V	V						V			V	V				V			V																					V														
T	2010	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module	V	V	V						V			V	V				V	V		V	V							V													V														
T	2010	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																					V														
T	2010	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																		
T	2010	ALL	Powertrain	Transmission Control Module	V	V																		V	V										V	V																							
T	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
T	2010	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																		
T	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																		
T	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
T	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
T	2010	ALL	Body	Passenger Presence System	V	V																			V																																		
T	2010	ALL	Body	Theft Deterrent Module	V	V																			V																																		
T	2010	ALL	Body	Radio	V																				V																																		
T	2010	ALL	Body	Remote Function Actuation		V																																																					
T	2011	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module	V	V											V							V	V																																		
T	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V	V				V			V																					V														
T	2011	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module	V	V	V						V			V	V				V	V		V	V							V													V														
T	2011	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V	V				V			V																					V														
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module	V	V	V						V			V	V				V			V																					V														
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module Argentia	V	V	V						V			V					V	V		V																					V														
T	2011	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																					V														
T	2011	ALL	Powertrain	(G)1.6L L4 LXV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																					V														
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																		
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V										V	V																							
T	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
T	2011	ALL	Chassis	Tire Pressure Monitor	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																			
T	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
T	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2011	ALL	Body	Passenger Presence System	V	V																			V																																			
T	2011	ALL	Body	Theft Deterrent Module	V	V																			V																																			
T	2011	ALL	Body	Radio	V																				V																																			
T	2011	ALL	Body	Remote Function Actuation		V																																																					
T	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module	V	V											V							V	V																																		
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
T	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
T	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
T	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																			
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																			
T	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
T	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
T	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V	V				V			V																						V													
T	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module	V	V	V						V			V	V				V	V		V	V							V														V													
T	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V	V				V			V																						V													
T	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module	V	V	V						V			V	V				V			V																						V													
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
T	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
T	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
T	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
T	2012	Aveo	Powertrain	Fuel Injector Control Module		V																		V	V																																			
T	2012	Aveo	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																										
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																			
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V										V	V																							
T	2012	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
T	2012	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
T	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
T	2012	Aveo	Chassis	Electric Power Steering Control Module	V	V																			V																																			
T	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
T	2012	Aveo	Chassis	Tire Pressure Monitor	V	V																			V																																			
T	2012	Aveo	Body	Body Control Module Hatchback	V	V																		V	V																																			
T	2012	Aveo	Body	Body Control Module Sedan	V	V																		V	V																																			
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
T	2012	Aveo	Body	Passenger Presence Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2012	Aveo	Body	Instrument Cluster	V	V																		V	V																																				
T	2012	Aveo	Body	Radio	V	V																		V	V																																			
T	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module	V	V																		V	V																																			
T	2012	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																			
T	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
T	2012	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			
T	2012	Aveo	Body	Front Seat Heating Control Module	V	V																		V	V																																			
T	2012	Aveo	Body	Remote Function Actuation		V																																																						
T	2012	Aveo	Body	Parking Assist Control Module	V	V																			V																																			
T	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module	V	V											V							V	V																																			
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V															V												
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V											
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V															V											
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V											
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																			
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																			
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V											
T	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
T	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module	V	V	V						V			V	V				V			V																						V												
T	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module	V	V	V						V			V	V				V	V		V	V							V														V												
T	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module	V	V	V						V			V	V				V			V																						V												
T	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module	V	V	V						V			V	V				V			V																						V												
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V	V											
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
T	2013	Aveo	Powertrain	Fuel Injector Control Module		V																		V	V																																			
T	2013	Aveo	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																										
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V																																			
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed	V	V																		V	V										V	V																							
T	2013	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
T	2013	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
T	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
T	2013	Aveo	Chassis	Electric Power Steering Control Module	V	V																			V																																			
T	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
T	2013	Aveo	Body	Body Control Module Hatchback	V	V																		V	V																																			
T	2013	Aveo	Body	Body Control Module Sedan	V	V																		V	V																																			
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
T	2013	Aveo	Body	Passenger Presence Module	V	V																			V																																			
T	2013	Aveo	Body	Instrument Cluster	V	V																		V	V																																			
T	2013	Aveo	Body	Radio	V	V																		V	V																																			
T	2013	Aveo	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
T	2013	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																			
T	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																			
T	2013	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Right Front Solenoid Valves	ABS Left Front Solenoid Valves	ABS Right Rear Solenoid Valves	ABS Left Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2013	Aveo	Body	Front Seat Heating Control Module	V	V																		V	V																																			
T	2013	Aveo	Body	Remote Function Actuation		V																																																					
T	2013	Aveo	Body	Parking Assist Control Module	V	V																			V																																		
T	2014	Aveo	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V					V		V	V																																	
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																	
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																	
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																	
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																	
T	2014	Aveo	Powertrain	1.4L L95 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
T	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module	V	V																		V	V										V	V	V																					
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission	V																			V	V				V	V		V														V												
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission	V																			V	V				V	V		V														V												
T	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module	V	V																		V	V										V	V	V																					
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
T	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
T	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
T	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
T	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
T	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
T	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module	V	V																		V	V										V	V	V																					
T	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
T	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V										V	V	V																					
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
T	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
T	2014	Aveo	Powertrain	1.6L LED Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V												
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V												
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
T	2014	Aveo	Powertrain	Chassis Control Module	V	V																		V	V							V		V																								
T	2014	Aveo	Powertrain	Fuel Injector Control Module		V																		V	V																																	
T	2014	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
T	2014	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																	
T	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
T	2014	Aveo	Chassis	Power Steering Control Module	V	V																			V																																	
T	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
T	2014	Aveo	Body	Body Control Module Hatchback	V	V																		V	V																																	
T	2014	Aveo	Body	Body Control Module Sedan	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																		
T	2014	Aveo	Body	Instrument Cluster	V	V																		V	V																																		
T	2014	Aveo	Body	Radio	V	V																		V	V																																		
T	2014	Aveo	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
T	2014	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
T	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
T	2014	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
T	2014	Aveo	Body	Front Seat Heating Control Module	V	V																		V	V																																		
T	2014	Aveo	Body	Keyless Entry Control Module		V																																																					
T	2014	Aveo	Body	Parking Assist Control Module	V	V																			V																																		
T	2015	Aveo	Powertrain	1.2L LMU Engine Control Module	V	V	V			V			V			V	V					V		V	V																																		
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V															V											
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V											
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																			V	V																																		
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																			V	V																																		
T	2015	Aveo	Powertrain	1.4L L95 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
T	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module	V	V																		V	V										V	V	V																					
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission	V																			V	V				V	V		V														V											
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission	V																			V	V				V	V		V														V											
T	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module	V	V																		V	V										V	V	V																					
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V											
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
T	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																	
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V											
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
T	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																	
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V											
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
T	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																	
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V											
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
T	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																	
T	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
T	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module	V	V																		V	V										V	V	V																					
T	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																											
T	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																		V	V										V	V	V																					
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V											
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
T	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																	
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V											
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
T	2015	Aveo	Powertrain	1.6L LED Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																	
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V											
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																	
T	2015	Aveo	Powertrain	Chassis Control Module	V	V																		V	V							V		V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2015	Aveo	Powertrain	Fuel Injector Control Module		V																	V	V																																				
T	2015	Aveo	Chassis	Electronic Brake Control Module	V	V																	V	V													V									V	V	V	V	V	V						
T	2015	Aveo	Chassis	Electronic Brake Control Module	V	V																	V	V																																		
T	2015	Aveo	Chassis	Power Steering Control Module	V	V																		V																																		
T	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																			V																																		
T	2015	Aveo	Body	Body Control Module Hatchback	V	V																	V	V																																		
T	2015	Aveo	Body	Body Control Module Sedan	V	V																	V	V																																		
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V					V	V																																		
T	2015	Aveo	Body	Instrument Cluster	V	V																	V	V																																		
T	2015	Aveo	Body	Radio	V	V																	V	V																																		
T	2015	Aveo	Body	Telematics Communication Interface Control Module	V	V																	V	V																																		
T	2015	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																	V	V																																		
T	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																	V	V																																		
T	2015	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																	V	V																																		
T	2015	Aveo	Body	Front Seat Heating Control Module	V	V																	V	V																																		
T	2015	Aveo	Body	Keyless Entry Control Module		V																																																				
T	2015	Aveo	Body	Parking Assist Control Module	V	V																		V																																		
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																		V	V																																		
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																		V	V																																		
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission	V																		V	V																																		
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission	V																		V	V																																		
T	2016	Aveo	Powertrain	1.4L L95 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																										
T	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module	V	V																		V	V									V	V	V																					
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
T	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
T	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module	V	V																	V	V				V	V	V	V				V	V	V	V	V																		
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
T	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
T	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																										
T	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module	V	V																		V	V									V	V	V																					
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
T	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
T	2016	Aveo	Powertrain	1.6L LED Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
T	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
T	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module	V	V	V			V			V			V	V			V	V			V	V							V																										
T	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module	V	V																	V	V										V	V	V																					
T	2016	Aveo	Powertrain	Chassis Control Module	V	V																	V	V							V		V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2016	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
T	2016	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V							
T	2016	Aveo	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V							
T	2016	Aveo	Chassis	Power Steering Control Module	V	V																			V																																		
T	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
T	2016	Aveo	Body	Body Control Module Hatchback	V	V																		V	V																																		
T	2016	Aveo	Body	Body Control Module Sedan	V	V																		V	V																																		
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V												V						V	V																																		
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
T	2016	Aveo	Body	Instrument Cluster	V	V																		V	V																																		
T	2016	Aveo	Body	Radio	V	V																		V	V																																		
T	2016	Aveo	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
T	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
T	2016	Aveo	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
T	2016	Aveo	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
T	2016	Aveo	Body	Front Seat Heating Control Module	V	V																		V	V																																		
T	2016	Aveo	Body	Parking Assist Control Module	V																			V	V																																		
T	2016	Aveo	Body	Keyless Entry Control Module		V																																																					
T	2016	Aveo	Body	Frontview Camera Module	V	V																		V	V																																		
U	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V																		V	V																				V														
U	2004	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module	V	V																		V	V																				V														
U	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																				V														
U	2004	ALL	Powertrain	ML4/MLQ 4 Speed Automatic	V	V																		V	V																																		
U	2004	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																		
U	2004	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
U	2004	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
U	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
U	2004	ALL	Body	Supplemental Inflatable Restraint	V																				V																																		
U	2004	ALL	Body	Remote Function Actuation		V																																																				
U	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V							V				V							V	V																																		
U	2005	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module	V	V							V				V							V	V																																		
U	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																				V														
U	2005	ALL	Powertrain	ML4/MLQ 4 Speed Automatic	V	V																		V	V																																		
U	2005	ALL	Powertrain	MFA Transmission Control Module 4 Speed	V	V																		V	V																																		
U	2005	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
U	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
U	2005	ALL	Body	Supplemental Inflatable Restraint	V																				V																																		
U	2005	ALL	Body	Remote Function Actuation		V																																																				
U	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V											V							V	V																				V														
U	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																				V														
U	2006	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																		
U	2006	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
U	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																																																			
U	2006	ALL	Body	Supplemental Inflatable Restraint	V																				V																																	
U	2006	ALL	Body	Remote Function Actuation		V																																																			
U	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V											V							V	V																				V														
U	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V	V				V			V																				V														
U	2007	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																		
U	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
U	2007	ALL	Body	Supplemental Inflatable Restraint	V																				V																																	
U	2007	ALL	Body	Supplemental Inflatable Restraint	V																				V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
U	2007	ALL	Body	Remote Function Actuation		V																																																							
U	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module	V	V											V						V	V																					V															
U	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module	V	V											V						V	V																					V															
U	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V	V				V			V																					V															
U	2008	ALL	Powertrain	Transmission Control Module	V	V																		V	V																																			
U	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
U	2008	ALL	Body	Supplemental Inflatable Restraint	V																				V																																			
U	2008	ALL	Body	Supplemental Inflatable Restraint	V																				V																																			
U	2008	ALL	Body	Remote Function Actuation		V																																																					
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2010	Sail	Powertrain	1.4L LCU Engine Control Module	V	V	V			V			V			V	V	V			V			V	V			V				V																											
U	2010	Sail	Powertrain	Transmission Control Module	V																			V	V										V																								
U	2010	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																														V				
U	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2011	Sail	Powertrain	1.4L LCU Engine Control Module	V	V	V			V			V			V	V	V			V			V	V			V				V																											
U	2011	Sail	Powertrain	Transmission Control Module	V																			V	V										V																								
U	2011	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																														V				
U	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																											
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																											
U	2012	Sail	Powertrain	Transmission Control Module	V																			V	V										V																								
U	2012	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																														V				
U	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																											
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																											
U	2013	Sail	Powertrain	Transmission Control Module	V																			V	V										V																								
U	2013	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																														V				
U	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																		
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																		
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																											
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																											
U	2014	Sail	Powertrain	Transmission Control Module	V																			V	V										V																								
U	2014	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																														V				
U	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																			
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission	V																			V	V																																			
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission	V																			V	V																																			
U	2015	Sail	Powertrain	1.3L LEW Engine Control Module	V																			V	V																																			
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																												
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																												
U	2015	Sail	Powertrain	1.5L L2B Engine Control Module	V																			V	V																																			
U	2015	Sail	Powertrain	Transmission Control Module	V																			V	V										V																									
U	2015	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																												V						
U	2015	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V						
U	2015	Sail	Chassis	Power Steering Control Module	V	V																			V																																		
U	2015	Sail	Body	Body Control Module	V	V																		V	V																																		
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
U	2015	Sail	Body	Radio/HVAC Control	V	V																		V	V																																		
U	2015	Sail	Body	HVAC Control Module	V	V																		V	V																																		
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission	V	V	V			V			V			V	V	V			V			V	V																																		
U	2016	Sail	Powertrain	1.2L LMU Transmission Control Module	V																			V	V										V																							
U	2016	Sail	Powertrain	1.3L LDV Engine Control Module	V																			V	V																																		
U	2016	Sail	Powertrain	1.3L LDV Transmission Control Module	V																			V	V										V																							
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission	V	V	V			V			V			V	V	V			V			V	V			V				V																											
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission	V	V	V			V			V		V	V	V	V			V	V		V	V			V				V																											
U	2016	Sail	Powertrain	1.4L LCU Transmission Control Module	V																			V	V										V																							
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission	V																			V	V																																		
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission	V																			V	V																																		
U	2016	Sail	Powertrain	1.5L L2B Transmission Control Module	V	V																		V	V										V	V	V	V																				
U	2016	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V																												V						
U	2016	Sail	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V						
U	2016	Sail	Chassis	Power Steering Control Module	V	V																			V																																		
U	2016	Sail	Body	Body Control Module	V	V																		V	V																																		
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
U	2016	Sail	Body	Radio/HVAC Control	V	V																		V	V																																		
U	2016	Sail	Body	Radio	V	V																		V	V																																		
U	2016	Sail	Body	HVAC Control Module	V	V																		V	V																																		
V	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																				V															
V	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V																		V	V																																		
V	2004	ALL	Powertrain	Transmission Control Module 4 Speed	V	V																		V	V																																		
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes	V	V																		V	V																																		
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control No	V	V																		V	V																																		
V	2004	ALL	Body	Supplemental Inflatable Restraint	V																				V																																		
V	2004	ALL	Body	ISU	V	V																		V																																		
V	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																				V															
V	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V																		V	V																																		
V	2005	ALL	Powertrain	Transmission Control Module 4 Speed	V	V																		V	V																																		
V	2005	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
V	2005	ALL	Body	Supplemental Inflatable Restraint	V																				V																																		
V	2005	ALL	Body	ISU	V	V																		V																																		
V	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module	V	V	V						V			V					V			V																				V															
V	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Right Front Solenoid Valves	ABS Left Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
V	2006	ALL	Powertrain	Transmission Control Module 4 Speed	V	V																		V	V																																					
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes	V	V																		V	V																																				
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control No	V	V																		V	V																																				
V	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																				
V	2006	ALL	Body	Supplemental Inflatable Restraint	V																				V																																				
V	2006	ALL	Body	ISU	V	V																		V																																				
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module	V	V											V							V	V																				V														
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector Control Module	V	V																		V	V																																			
V	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module	V	V	V						V			V	V				V			V																				V																
V	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module	V	V													V					V	V					V	V																													
V	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module	V	V											V							V	V																				V															
V	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V											V							V	V																				V															
V	2007	ALL	Powertrain	Transmission Control Module 4 Speed	V	V																		V	V																																				
V	2007	ALL	Powertrain	Transmission Control Module 5 Speed	V	V																		V	V									V	V	V																								
V	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
V	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																				
V	2007	ALL	Body	ISU	V	V																		V																																				
V	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																				V															
V	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																				V															
V	2008	ALL	Powertrain	Transmission Control Module 6 Speed	V	V																		V										V	V	V																								
V	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
V	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																				
V	2008	ALL	Body	ISU	V	V																		V																																				
V	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																				V															
V	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																				V															
V	2009	ALL	Powertrain	Transmission Control Module 6 Speed	V	V																		V										V	V	V																								
V	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
V	2009	ALL	Body	ISU	V	V																		V																																				
V	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module	V	V	V												V					V	V					V	V																													
V	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																				V															
V	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																				V															
V	2010	ALL	Powertrain	Transmission Control Module 6 Speed	V	V																		V										V	V	V																								
V	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
V	2010	ALL	Body	ISU	V	V																		V																																				
V	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module	V	V	V												V					V	V					V	V																													
V	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																				V															
V	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module	V	V	V						V				V	V	V		V	V		V	V																				V															
V	2011	ALL	Powertrain	Transmission Control Module 6 Speed	V	V																		V										V	V	V																								
V	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
V	2011	ALL	Body	ISU	V	V																		V																																				
W	2004	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module	V	V							V			V					V			V	V							V																													
W	2004	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module	V	V							V			V					V			V	V							V																													
W	2004	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module	V	V							V			V					V			V	V							V																													
W	2004	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V																								
W	2004	ALL	Body	Body Control Module	V	V																		V																																				
W	2004	ALL	Body	Digital Radio Receiver	V	V																			V																																			
W	2004	ALL	Body	Driver Information Center	V																																																						
W	2004	ALL	Body	Heating and Air Conditioning	V																																																						
W	2004	ALL	Body	Instrument Panel Cluster	V	V																		V																																				
W	2004	ALL	Body	Personalization																																																							
W	2004	ALL	Body	Radio	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
W	2004	ALL	Body	Supplemental Inflatable Restraint	V																																																										
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module	V	V							V			V					V			V	V							V																														
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module	V	V							V			V					V			V	V							V																														
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module	V	V							V			V					V			V	V							V																														
W	2005	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																									
W	2005	ALL	Body	Body Control Module	V	V																		V																																					
W	2005	ALL	Body	Digital Radio Receiver	V	V																			V																																				
W	2005	ALL	Body	Driver Information Center	V																																																							
W	2005	ALL	Body	Heating and Air Conditioning	V																																																							
W	2005	ALL	Body	Instrument Panel Cluster	V	V																		V																																					
W	2005	ALL	Body	Personalization																																																								
W	2005	ALL	Body	Radio	V	V																		V																																					
W	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																										V												
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V															
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V															
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V															
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V															
W	2006	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																									
W	2006	ALL	Chassis	Anti-lock Brake System	V	V																			V																																				
W	2006	ALL	Body	Digital Radio Receiver	V	V																			V																																				
W	2006	ALL	Body	Radio	V	V																		V	V																																				
W	2006	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																				
W	2006	ALL	Body	Seat	V	V																			V																																				
W	2006	ALL	Body	Theft Deterrent Module	V	V																			V																																				
W	2006	ALL	Body	Body Control Module	V	V																			V																																				
W	2006	ALL	Body	HVAC C67 Single	V	V																		V	V																																				
W	2006	ALL	Body	HVAC CJ3 Dual	V	V																		V	V																																				
W	2006	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
W	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																				
W	2006	ALL	Body	Passenger Presence System	V	V																			V																																				
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V															
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
W	2007	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																									
W	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
W	2007	ALL	Body	Body Control Module	V	V																		V	V																																				
W	2007	ALL	Body	Digital Radio Receiver	V	V																			V																																				
W	2007	ALL	Body	Heated Seat Module	V	V																			V																																				
W	2007	ALL	Body	HVAC C67 Single	V	V																		V	V																																				
W	2007	ALL	Body	HVAC CJ3 Dual	V	V																		V	V																																				
W	2007	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																				
W	2007	ALL	Body	Passenger Presence System	V	V																			V																																				
W	2007	ALL	Body	Radio	V	V																		V	V																																				
W	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																				
W	2007	ALL	Body	Theft Deterrent Module	V	V																			V																																				
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V															
W	2008	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
W	2008	ALL	Chassis	Electronic Brake Control Module	V	V																			V																																				
W	2008	ALL	Body	Body Control Module	V	V																		V	V																																			
W	2008	ALL	Body	Digital Radio Receiver	V	V																			V																																			
W	2008	ALL	Body	Heated Seat Module	V	V																			V																																			
W	2008	ALL	Body	HVAC C67 Single	V	V																		V	V																																			
W	2008	ALL	Body	HVAC CJ3 Dual	V	V																		V	V																																			
W	2008	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
W	2008	ALL	Body	Passenger Presence System	V	V																			V																																			
W	2008	ALL	Body	Radio	V	V																		V	V																																			
W	2008	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
W	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
W	2008	ALL	Body	Theft Deterrent Module	V	V																			V																																			
W	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
W	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
W	2009	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
W	2009	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
W	2009	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																								
W	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
W	2009	ALL	Body	Body Control Module	V	V																		V	V																																			
W	2009	ALL	Body	Digital Radio Receiver	V	V																			V																																			
W	2009	ALL	Body	Heated Seat Module	V	V																			V																																			
W	2009	ALL	Body	HVAC C67 Single	V	V																		V	V																																			
W	2009	ALL	Body	HVAC CJ3 Dual	V	V																		V	V																																			
W	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
W	2009	ALL	Body	Passenger Presence System	V	V																			V																																			
W	2009	ALL	Body	Radio	V	V																		V	V																																			
W	2009	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
W	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
W	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																			
W	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
W	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
W	2010	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
W	2010	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																								
W	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
W	2010	ALL	Body	Body Control Module	V	V																		V	V																																			
W	2010	ALL	Body	Digital Radio Receiver	V	V																			V																																			
W	2010	ALL	Body	Heated Seat Module	V	V																			V																																			
W	2010	ALL	Body	HVAC C67 Single	V	V																		V	V																																			
W	2010	ALL	Body	HVAC CJ3 Dual	V	V																		V	V																																			
W	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
W	2010	ALL	Body	Passenger Presence System	V	V																			V																																			
W	2010	ALL	Body	Radio	V	V																		V	V																																			
W	2010	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
W	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
W	2010	ALL	Body	Theft Deterrent Module	V	V																			V																																			
W	2011	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
W	2011	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
W	2011	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																								
W	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
W	2011	ALL	Body	Body Control Module	V	V																		V	V																																			
W	2011	ALL	Body	Digital Radio Receiver	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
W	2011	ALL	Body	Heated Seat Module	V	V																			V																																			
W	2011	ALL	Body	HVAC C67 Single	V	V																		V	V																																			
W	2011	ALL	Body	HVAC CJ3 Dual	V	V																		V	V																																			
W	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
W	2011	ALL	Body	Passenger Presence System	V	V																			V																																			
W	2011	ALL	Body	Radio	V	V																		V	V																																			
W	2011	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
W	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
W	2011	ALL	Body	Theft Deterrent Module	V	V																			V																																			
W	2012	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V														V													
W	2012	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																						
W	2012	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
W	2012	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
W	2012	ALL	Body	Body Control Module	V	V																		V	V																																			
W	2012	ALL	Body	Digital Radio Receiver	V	V																			V																																			
W	2012	ALL	Body	Heated Seat Module	V	V																			V																																			
W	2012	ALL	Body	HVAC C67 Single	V	V																		V	V																																			
W	2012	ALL	Body	HVAC CJ3 Dual	V	V																		V	V																																			
W	2012	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
W	2012	ALL	Body	Passenger Presence System	V	V																			V																																			
W	2012	ALL	Body	Radio	V	V																		V	V																																			
W	2012	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
W	2012	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
W	2012	ALL	Body	Theft Deterrent Module	V	V																			V																																			
W	2013	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V													
W	2013	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																						
W	2013	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
W	2013	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
W	2013	ALL	Body	Body Control Module	V	V																		V	V																																			
W	2013	ALL	Body	Digital Radio Receiver	V	V																			V																																			
W	2013	ALL	Body	Heated Seat Module	V	V																			V																																			
W	2013	ALL	Body	HVAC C67 Single	V	V																		V	V																																			
W	2013	ALL	Body	HVAC CJ3 Dual	V	V																		V	V																																			
W	2013	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
W	2013	ALL	Body	Passenger Presence System	V	V																			V																																			
W	2013	ALL	Body	Radio	V	V																		V	V																																			
W	2013	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
W	2013	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
W	2013	ALL	Body	Theft Deterrent Module	V	V																			V																																			
W	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V		V													
W	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V								V													
W	2014	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module	V	V																		V	V							V		V																									
W	2014	Impala	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V					V
W	2014	Impala	Body	Body Control Module	V	V																		V	V																																			
W	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
W	2014	Impala	Body	Passenger Presence Module	V	V																			V																																			
W	2014	Impala	Body	Instrument Cluster	V	V																		V	V																																			
W	2014	Impala	Body	Radio	V	V																		V	V																																			
W	2014	Impala	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
W	2014	Impala	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
W	2014	Impala	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
W	2014	Impala	Body	Front Seat Heating Control Module	V	V																			V																																			
W	2014	Impala	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
W	2014	Impala	Body	Theft Deterrent Module	V	V																			V																																			
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission	V																			V	V	V			V	V	V	V	V													V													
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission	V																			V	V	V			V	V	V	V	V												V	V													
W	2014	Lumina	Powertrain	(2) 6.0L L77 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
W	2014	Lumina	Powertrain	Fuel Injector Control Module		V																		V	V																																			
W	2014	Lumina	Powertrain	Chassis Control Module	V	V																		V	V							V		V																										
W	2014	Lumina	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
W	2014	Lumina	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
W	2014	Lumina	Chassis	Power Steering Control Module	V	V																			V																																			
W	2014	Lumina	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
W	2014	Lumina	Chassis	Suspension Control Module	V	V																			V																																			
W	2014	Lumina	Body	Body Control Module Coupe	V	V																		V	V																																			
W	2014	Lumina	Body	Body Control Module Sedan	V	V																		V	V																																			
W	2014	Lumina	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
W	2014	Lumina	Body	Instrument Cluster	V	V																		V	V																																			
W	2014	Lumina	Body	Head-Up Display Module	V																			V	V																																			
W	2014	Lumina	Body	Radio Control	V																			V	V																																			
W	2014	Lumina	Body	HVAC Control	V	V																		V	V																																			
W	2014	Lumina	Body	Headlamp Control Module	V	V																		V	V																						V													
W	2014	Lumina	Body	Trailer Interface Control Module	V	V																		V	V																																			
W	2014	Lumina	Body	Radio	V	V																		V	V																																			
W	2014	Lumina	Body	HVAC Control Module	V	V																		V	V																																			
W	2014	Lumina	Body	Keyless Entry Control Module	V	V																		V	V																																			
W	2014	Lumina	Body	Right Side Object Detection Control Module	V																			V	V																																			
W	2014	Lumina	Body	Left Side Object Detection Control Module	V																			V	V																																			
W	2014	Lumina	Body	Parking Assist Control Module	V	V																		V	V																																			
W	2014	Lumina	Body	Frontview Camera Module	V	V																		V	V																																			
W	2014	Lumina	Body	Steering Column Lock Control Module	V	V																			V																																			
W	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V			V	V	V	V	V								V	V	V	V	V	V														
W	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V													
W	2015	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module	V	V																		V	V							V		V																									
W	2015	Impala	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
W	2015	Impala	Body	Body Control Module	V	V																		V	V																																			
W	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
W	2015	Impala	Body	Passenger Presence Module	V	V																			V																																			
W	2015	Impala	Body	Instrument Cluster	V	V																		V	V																																			
W	2015	Impala	Body	Radio	V	V																		V	V																																			
W	2015	Impala	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
W	2015	Impala	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
W	2015	Impala	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
W	2015	Impala	Body	Front Seat Heating Control Module	V	V																			V																																			
W	2015	Impala	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
W	2015	Impala	Body	Theft Deterrent Module	V	V																			V																																			
W	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V														
W	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
W	2016	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module	V	V																		V	V							V		V																										
W	2016	Impala	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
W	2016	Impala	Body	Body Control Module	V	V																		V	V																																		
W	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
W	2016	Impala	Body	Passenger Presence Module	V	V																			V																																		
W	2016	Impala	Body	Instrument Cluster	V	V																		V	V																																		
W	2016	Impala	Body	Radio	V	V																		V	V																																		
W	2016	Impala	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
W	2016	Impala	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
W	2016	Impala	Body	HVAC Manual Control Dual Zone (CJ2)	V	V																		V	V																																		
W	2016	Impala	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																		
W	2016	Impala	Body	Front Seat Heating Control Module	V	V																			V																																		
W	2016	Impala	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
W	2016	Impala	Body	Theft Deterrent Module	V	V																			V																																		
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Auto	V	V										V	V				V	V		V	V							V														V												
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Manual	V	V										V	V				V	V		V	V							V														V												
Y	2004	ALL	Powertrain	(S)5.7L V8 LS6 Engine Control Module	V	V										V	V				V	V		V	V							V														V												
Y	2004	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																						
Y	2004	ALL	Chassis	RTD	V	V																		V	V																																		
Y	2004	ALL	Body	Body Control Module	V	V																		V																																		
Y	2004	ALL	Body	Heating and Air Conditioning	V	V																		V																																		
Y	2004	ALL	Body	Instrument Panel Cluster	V	V																		V																																		
Y	2004	ALL	Body	Left Door Control Module	V	V																		V																																		
Y	2004	ALL	Body	Radio	V	V																																																			
Y	2004	ALL	Body	Remote Function Actuation	V	V																																																			
Y	2004	ALL	Body	Right Door Control Module	V	V																		V																																		
Y	2004	ALL	Body	Seat Control Module	V	V																		V																																		
Y	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																			
Y	2005	ALL	Powertrain	Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V												
Y	2005	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																						
Y	2005	ALL	Chassis	Electronic Brake Control Module	V	V																			V																																		
Y	2005	ALL	Chassis	Electronic Suspension Control	V	V																		V																																		
Y	2005	ALL	Chassis	Steering Wheel and Column	V	V																																																			
Y	2005	ALL	Body	Amplifier	V	V																		V																																		
Y	2005	ALL	Body	Body Control Module	V	V																		V	V																																		
Y	2005	ALL	Body	Digital Radio Receiver	V	V																			V																																		
Y	2005	ALL	Body	Driver Door Module	V	V																		V	V																					V												
Y	2005	ALL	Body	Driver Door Switch	V	V																			V																																		
Y	2005	ALL	Body	Driver Position Module	V	V																		V																																		
Y	2005	ALL	Body	Folding Top Module	V	V																		V																																		
Y	2005	ALL	Body	Head Up Display	V	V																		V	V																																		
Y	2005	ALL	Body	HVAC Control Module	V	V																		V	V																																		
Y	2005	ALL	Body	Instrument Panel Cluster	V	V																		V																																		
Y	2005	ALL	Body	Navigation Radio	V	V																																																			
Y	2005	ALL	Body	Passenger Door Module	V	V																		V	V																					V												
Y	2005	ALL	Body	Radio	V	V																		V	V																					V												
Y	2005	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
Y	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																			
Y	2006	ALL	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V												
Y	2006	ALL	Powertrain	Exhaust Flow Control Module	V	V																		V	V																																		
Y	2006	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Y	2006	ALL	Chassis	Electronic Brake Control Module	V	V																			V																																			
Y	2006	ALL	Chassis	Electronic Suspension Control	V	V																		V																																			
Y	2006	ALL	Chassis	Steering Wheel and Column	V	V																																																					
Y	2006	ALL	Body	Body Control Module	V	V																		V	V																																		
Y	2006	ALL	Body	CD Changer	V	V																																																					
Y	2006	ALL	Body	Digital Radio Receiver	V	V																			V																																		
Y	2006	ALL	Body	Driver Door Module	V	V																		V	V																						V											
Y	2006	ALL	Body	Driver Door Switch	V	V																			V																																		
Y	2006	ALL	Body	Driver Position Module	V	V																		V																																		
Y	2006	ALL	Body	Folding Top Module	V	V																		V																																		
Y	2006	ALL	Body	Head Up Display	V	V																		V	V																																		
Y	2006	ALL	Body	HVAC Control Module	V	V																		V	V																																		
Y	2006	ALL	Body	Instrument Panel Cluster	V	V																		V																																		
Y	2006	ALL	Body	Navigation Radio	V	V																																																				
Y	2006	ALL	Body	Passenger Door Module	V	V																		V	V																						V											
Y	2006	ALL	Body	Radio	V	V																		V	V																						V											
Y	2006	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
Y	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
Y	2007	ALL	Powertrain	Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V																				V															
Y	2007	ALL	Powertrain	Exhaust Flow Control Module	V	V																	V	V																																		
Y	2007	ALL	Powertrain	Transmission Control Module	V	V																	V											V	V	V																						
Y	2007	ALL	Chassis	Electronic Brake Control Module	V	V																	V	V																																		
Y	2007	ALL	Chassis	Electronic Suspension Control	V	V																	V	V																																		
Y	2007	ALL	Body	Body Control Module	V	V																	V	V																																		
Y	2007	ALL	Body	CD Changer	V	V																																																				
Y	2007	ALL	Body	Digital Radio Receiver	V	V																			V																																		
Y	2007	ALL	Body	Driver Door Module	V	V																		V	V																						V											
Y	2007	ALL	Body	Driver Door Switch	V	V																			V																																		
Y	2007	ALL	Body	Driver Position Module	V	V																		V																																		
Y	2007	ALL	Body	Folding Top Module	V	V																		V																																		
Y	2007	ALL	Body	Head Up Display	V	V																		V	V																																		
Y	2007	ALL	Body	HVAC Control Module	V	V																		V	V																																		
Y	2007	ALL	Body	Instrument Panel Cluster	V	V																		V																																		
Y	2007	ALL	Body	Navigation Radio	V	V																																																				
Y	2007	ALL	Body	Passenger Door Module	V	V																		V	V																						V											
Y	2007	ALL	Body	Radio	V	V																		V	V																						V											
Y	2007	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
Y	2007	ALL	Body	Steering Column Lock Module	V	V																																																				
Y	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
Y	2008	ALL	Powertrain	Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V																				V															
Y	2008	ALL	Powertrain	Exhaust Flow Control Module	V	V																	V	V																																		
Y	2008	ALL	Powertrain	Transmission Control Module	V	V																	V											V	V	V																						
Y	2008	ALL	Chassis	Electronic Brake Control Module	V	V																	V	V																																		
Y	2008	ALL	Chassis	Electronic Suspension Control	V	V																	V	V																																		
Y	2008	ALL	Body	Body Control Module	V	V																	V	V																																		
Y	2008	ALL	Body	CD Changer	V	V																																																				
Y	2008	ALL	Body	Digital Radio Receiver	V	V																			V																																		
Y	2008	ALL	Body	Driver Door Module	V	V																		V	V																						V											
Y	2008	ALL	Body	Driver Door Switch	V	V																			V																																		
Y	2008	ALL	Body	Driver Position Module	V	V																		V																																		
Y	2008	ALL	Body	Folding Top Module	V	V																		V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Y	2008	ALL	Body	Head Up Display	V	V																		V	V																																				
Y	2008	ALL	Body	HVAC Control Module	V	V																		V	V																																				
Y	2008	ALL	Body	Instrument Panel Cluster	V	V																		V																																					
Y	2008	ALL	Body	Navigation Radio	V	V																																																						
Y	2008	ALL	Body	Passenger Door Module	V	V																		V	V																							V													
Y	2008	ALL	Body	Radio	V	V																			V																							V												
Y	2008	ALL	Body	Personal Audio Link Module	V																				V																																				
Y	2008	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
Y	2008	ALL	Body	Steering Column Lock Module	V	V																																																						
Y	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V															
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module	V	V																		V	V																																				
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module	V	V																		V										V	V	V																								
Y	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
Y	2009	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																				
Y	2009	ALL	Body	Body Control Module	V	V																		V	V																																				
Y	2009	ALL	Body	CD Changer	V	V																																																						
Y	2009	ALL	Body	Digital Radio Receiver	V	V																			V																																				
Y	2009	ALL	Body	Driver Door Module	V	V																		V	V																							V													
Y	2009	ALL	Body	Driver Door Switch	V	V																			V																																				
Y	2009	ALL	Body	Driver Position Module	V	V																		V																																					
Y	2009	ALL	Body	Folding Top Module	V	V																		V																																					
Y	2009	ALL	Body	Head Up Display	V	V																		V	V																																				
Y	2009	ALL	Body	HVAC Control Module	V	V																		V	V																																				
Y	2009	ALL	Body	Instrument Panel Cluster	V	V																		V																																					
Y	2009	ALL	Body	Navigation Radio	V	V																																																						
Y	2009	ALL	Body	Passenger Door Module	V	V																		V	V																							V													
Y	2009	ALL	Body	Radio	V	V																			V																							V													
Y	2009	ALL	Body	Personal Audio Link Module	V																				V																																				
Y	2009	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
Y	2009	ALL	Body	Steering Column Lock Module	V	V																																																						
Y	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V															
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module	V	V																		V	V																																				
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module	V	V																		V										V	V	V																								
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V															
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module	V	V																		V	V																																				
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module	V	V																		V	V																																				
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V															
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module	V	V																		V	V																																				
Y	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
Y	2010	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																				
Y	2010	ALL	Body	Body Control Module	V	V																		V	V																																				
Y	2010	ALL	Body	CD Changer	V	V																																																						
Y	2010	ALL	Body	Digital Radio Receiver	V	V																			V																																				
Y	2010	ALL	Body	Driver Door Module	V	V																		V	V																							V													
Y	2010	ALL	Body	Driver Door Switch	V	V																			V																																				
Y	2010	ALL	Body	Driver Position Module	V	V																		V																																					
Y	2010	ALL	Body	Folding Top Module	V	V																		V																																					
Y	2010	ALL	Body	Head Up Display	V	V																		V	V																																				
Y	2010	ALL	Body	HVAC Control Module	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Y	2010	ALL	Body	Instrument Panel Cluster	V	V																		V																																						
Y	2010	ALL	Body	Navigation Radio	V	V																																																							
Y	2010	ALL	Body	Passenger Door Module	V	V																		V	V																							V													
Y	2010	ALL	Body	Radio	V	V																			V																							V													
Y	2010	ALL	Body	Personal Audio Link Module	V																				V																																					
Y	2010	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																					
Y	2010	ALL	Body	Steering Column Lock Module	V	V																																																							
Y	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																																																							
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V																
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module	V	V																		V	V																																					
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module	V	V																		V										V	V	V																									
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V																
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module	V	V																		V	V																																					
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module	V	V																		V	V																																					
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V																
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module	V	V																		V	V																																					
Y	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
Y	2011	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																					
Y	2011	ALL	Body	Body Control Module	V	V																		V	V																																					
Y	2011	ALL	Body	CD Changer	V	V																																																							
Y	2011	ALL	Body	Digital Radio Receiver	V	V																			V																																					
Y	2011	ALL	Body	Driver Door Module	V	V																		V	V																							V													
Y	2011	ALL	Body	Driver Door Switch	V	V																			V																																					
Y	2011	ALL	Body	Driver Position Module	V	V																		V																																					
Y	2011	ALL	Body	Folding Top Module	V	V																		V																																					
Y	2011	ALL	Body	Head Up Display	V	V																		V	V																																				
Y	2011	ALL	Body	HVAC Control Module	V	V																		V	V																																				
Y	2011	ALL	Body	Instrument Panel Cluster	V	V																		V																																					
Y	2011	ALL	Body	Navigation Radio	V	V																																																						
Y	2011	ALL	Body	Passenger Door Module	V	V																		V	V																							V													
Y	2011	ALL	Body	Radio	V	V																			V																							V													
Y	2011	ALL	Body	Personal Audio Link Module	V																				V																																					
Y	2011	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																					
Y	2011	ALL	Body	Steering Column Lock Module	V	V																																																							
Y	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																																																							
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V																
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module	V	V																		V	V																																					
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module	V	V																		V										V	V	V																									
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V																
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module	V	V																		V	V																																					
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module	V	V																		V	V																																					
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V																
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module	V	V																		V	V																																					
Y	2012	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
Y	2012	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																					
Y	2012	ALL	Body	Body Control Module	V	V																		V	V																																					
Y	2012	ALL	Body	CD Changer	V	V																																																							
Y	2012	ALL	Body	Digital Radio Receiver	V	V																			V																																					
Y	2012	ALL	Body	Driver Door Module	V	V																		V	V																							V													
Y	2012	ALL	Body	Driver Door Switch	V	V																			V																																					
Y	2012	ALL	Body	Driver Position Module	V	V																		V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Y	2012	ALL	Body	Folding Top Module	V	V																		V																																					
Y	2012	ALL	Body	Head Up Display	V	V																		V	V																																			
Y	2012	ALL	Body	HVAC Control Module	V	V																		V	V																																			
Y	2012	ALL	Body	Instrument Panel Cluster	V	V																		V																																				
Y	2012	ALL	Body	Navigation Radio	V	V																																																					
Y	2012	ALL	Body	Passenger Door Module	V	V																		V	V																						V												
Y	2012	ALL	Body	Radio	V	V																			V																						V												
Y	2012	ALL	Body	Personal Audio Link Module	V																				V																																			
Y	2012	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
Y	2012	ALL	Body	Steering Column Lock Module	V	V																																																					
Y	2012	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module	V	V																		V	V																																			
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module	V	V																		V										V	V	V																							
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module	V	V																		V	V																																			
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module	V	V																		V	V																																			
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module	V	V																		V	V																																			
Y	2013	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
Y	2013	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
Y	2013	ALL	Body	Body Control Module	V	V																		V	V																																			
Y	2013	ALL	Body	CD Changer	V	V																																																					
Y	2013	ALL	Body	Digital Radio Receiver	V	V																			V																																			
Y	2013	ALL	Body	Driver Door Module	V	V																		V	V																						V												
Y	2013	ALL	Body	Driver Door Switch	V	V																			V																																			
Y	2013	ALL	Body	Driver Position Module	V	V																		V																																			
Y	2013	ALL	Body	Folding Top Module	V	V																		V																																			
Y	2013	ALL	Body	Head Up Display	V	V																		V	V																																			
Y	2013	ALL	Body	HVAC Control Module	V	V																		V	V																																			
Y	2013	ALL	Body	Instrument Panel Cluster	V	V																		V																																				
Y	2013	ALL	Body	Navigation Radio	V	V																																																					
Y	2013	ALL	Body	Passenger Door Module	V	V																		V	V																						V												
Y	2013	ALL	Body	Radio	V	V																			V																						V												
Y	2013	ALL	Body	Personal Audio Link Module	V																				V																																			
Y	2013	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
Y	2013	ALL	Body	Steering Column Lock Module	V	V																																																					
Y	2013	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V														
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V											V	V														
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module	V	V																		V	V									V	V	V	V										V												
Y	2014	Corvette	Powertrain	Chassis Control Module	V																																																					
Y	2014	Corvette	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
Y	2014	Corvette	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
Y	2014	Corvette	Chassis	Power Steering Control Module	V	V																			V																																			
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
Y	2014	Corvette	Chassis	Suspension Control Module	V	V																		V	V																																			
Y	2014	Corvette	Body	Body Control Module Convertible	V	V																		V	V																																			
Y	2014	Corvette	Body	Body Control Module Coupe	V	V																		V	V																																			
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
Y	2014	Corvette	Body	Passenger Presence Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Y	2014	Corvette	Body	Instrument Cluster	V	V																		V	V																																			
Y	2014	Corvette	Body	Radio/HVAC Control	V																				V																																			
Y	2014	Corvette	Body	Inside Rearview Mirror	V	V																		V	V																																			
Y	2014	Corvette	Body	Radio	V	V																		V	V																																			
Y	2014	Corvette	Body	Amplifier	V	V																			V																																			
Y	2014	Corvette	Body	Human Machine Interface Control Module	V	V																		V	V																						V													
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
Y	2014	Corvette	Body	HVAC Control Module	V	V																		V	V																																			
Y	2014	Corvette	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
Y	2014	Corvette	Body	Seat Memory Control Module - Driver	V	V																		V	V																																			
Y	2014	Corvette	Body	Folding Top Control Module	V	V																		V	V																																			
Y	2014	Corvette	Body	Keyless Entry Control Module	V	V																		V	V																																			
Y	2014	Corvette	Body	Steering Column Lock Control Module	V	V																			V																																			
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V													
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V													
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module	V	V																		V	V									V	V	V	V		V																				
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V													
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V													
Y	2015	Corvette	Powertrain	6.2L LT4 Transmission Control Module	V	V																		V	V									V	V	V	V		V																				
Y	2015	Corvette	Powertrain	Chassis Control Module	V																																																						
Y	2015	Corvette	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V	V						
Y	2015	Corvette	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
Y	2015	Corvette	Chassis	Power Steering Control Module	V	V																			V																																			
Y	2015	Corvette	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
Y	2015	Corvette	Chassis	Suspension Control Module	V	V																		V	V																																			
Y	2015	Corvette	Body	Body Control Module Convertible	V	V																		V	V																																			
Y	2015	Corvette	Body	Body Control Module Coupe	V	V																		V	V																																			
Y	2015	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
Y	2015	Corvette	Body	Passenger Presence Module	V	V																			V																																			
Y	2015	Corvette	Body	Instrument Cluster	V	V																		V	V																																			
Y	2015	Corvette	Body	Radio/HVAC Control	V																				V																																			
Y	2015	Corvette	Body	Vehicle Performance Data Recorder	V																				V																																			
Y	2015	Corvette	Body	Inside Rearview Mirror	V	V																		V	V																																			
Y	2015	Corvette	Body	Radio	V	V																		V	V																																			
Y	2015	Corvette	Body	Amplifier	V	V																			V																																			
Y	2015	Corvette	Body	Human Machine Interface Control Module	V	V																		V	V																					V													
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
Y	2015	Corvette	Body	HVAC Control Module	V	V																		V	V																																			
Y	2015	Corvette	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
Y	2015	Corvette	Body	Seat Memory Control Module - Driver	V																																																						
Y	2015	Corvette	Body	Folding Top Control Module	V	V																		V	V																																			
Y	2015	Corvette	Body	Keyless Entry Control Module	V	V																		V	V																																			
Y	2015	Corvette	Body	Steering Column Lock Control Module	V	V																			V																																			
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V													
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V													
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V		V																				
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V													
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V													
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V		V																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Y	2016	Corvette	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																					V													
Y	2016	Corvette	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V							
Y	2016	Corvette	Chassis	Parking Brake Control Module	V	V																			V																				V								V	V	V	V		
Y	2016	Corvette	Chassis	Power Steering Control Module	V	V																			V																																		
Y	2016	Corvette	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
Y	2016	Corvette	Chassis	Suspension Control Module	V	V																		V	V																																		
Y	2016	Corvette	Body	Body Control Module	V	V																		V	V																																		
Y	2016	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
Y	2016	Corvette	Body	Passenger Presence Module	V	V																			V																																		
Y	2016	Corvette	Body	Instrument Cluster	V	V																		V	V																																		
Y	2016	Corvette	Body	Radio/HVAC Control	V																				V																																		
Y	2016	Corvette	Body	Vehicle Performance Data Recorder	V																				V																																		
Y	2016	Corvette	Body	Video Processing Control Module	V	V																		V	V																																		
Y	2016	Corvette	Body	Inside Rearview Mirror	V	V																		V	V																																		
Y	2016	Corvette	Body	Radio	V	V																		V	V																																		
Y	2016	Corvette	Body	Amplifier	V	V																			V																																		
Y	2016	Corvette	Body	Human Machine Interface Control Module	V	V																		V	V																					V													
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
Y	2016	Corvette	Body	HVAC Control Module	V	V																		V	V																																		
Y	2016	Corvette	Body	Liftgate Control Module	V	V																			V																					V													
Y	2016	Corvette	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																		
Y	2016	Corvette	Body	Seat Memory Control Module - Driver	V																																																					
Y	2016	Corvette	Body	Folding Top Control Module	V	V																		V	V																																		
Y	2016	Corvette	Body	Keyless Entry Control Module	V	V																		V	V																																		
Y	2016	Corvette	Body	Steering Column Lock Control Module	V	V																			V																																		
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V													
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V											V	V													
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V													
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V											V	V													
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V													
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V											V	V													
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V												V													
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V													
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
Y	2016	Cruze	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V				V		
Y	2016	Cruze	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
Y	2016	Cruze	Chassis	Power Steering Control Module	V	V																			V																																		
Y	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
Y	2016	Cruze	Body	Body Control Module	V	V																		V	V																																		
Y	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
Y	2016	Cruze	Body	Passenger Presence Module	V	V																			V																																		
Y	2016	Cruze	Body	Instrument Cluster	V	V																		V	V																																		
Y	2016	Cruze	Body	Radio Controls	V																				V																																		
Y	2016	Cruze	Body	HVAC Controls	V																			V	V																																		
Y	2016	Cruze	Body	Trailer Interface Control Module	V	V																		V	V																																		
Y	2016	Cruze	Body	Radio Base (IO3 IO7)	V	V																		V	V																																		
Y	2016	Cruze	Body	Radio (IOA)	V	V																		V	V																																		
Y	2016	Cruze	Body	Radio (IOB)	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Y	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)	V	V																		V	V																																					
Y	2016	Cruze	Body	Amplifier	V	V																			V																																					
Y	2016	Cruze	Body	Multimedia Player Interface Module	V	V																			V																																					
Y	2016	Cruze	Body	Human Machine Interface Control Module	V	V																		V	V																							V													
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																					
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																					
Y	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																					
Y	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)	V	V																		V	V																																					
Y	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																					
Y	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																					
Y	2016	Cruze	Body	Keyless Entry Control Module	V	V																		V	V																																					
Y	2016	Cruze	Body	Right Side Object Detection Control Module	V																			V	V																																					
Y	2016	Cruze	Body	Left Side Object Detection Control Module	V																			V	V																																					
Y	2016	Cruze	Body	Parking Assist Control Module	V																			V	V																																					
Y	2016	Cruze	Body	Frontview Camera Module	V	V																		V	V																																					
Y	2016	Cruze	Body	Steering Column Lock Control Module	V	V																			V																																					
Y	2016	Cruze	Body	Long Range Radar Sensor Module	V	V																			V																																					
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V																
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module	V	V																		V											V	V																									
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V																													
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Transmission Control Module	V	V																		V											V	V																									
Z	2004	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
Z	2004	ALL	Chassis	Power Steering Control Module	V	V																		V																																					
Z	2004	ALL	Body	Body Control Module	V	V																		V	V																																					
Z	2004	ALL	Body	Digital Radio Receiver	V	V																			V																																					
Z	2004	ALL	Body	HVAC Control Module	V	V																		V	V																																					
Z	2004	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																					
Z	2004	ALL	Body	Radio	V																																																								
Z	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																					
Z	2004	ALL	Body	Theft Deterrent Module	V	V																			V																																					
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V																
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module	V	V																		V											V	V																									
Z	2005	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module	V	V	V						V			V		V			V	V		V	V																					V														
Z	2005	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
Z	2005	ALL	Chassis	Power Steering Control Module	V	V																		V																																					
Z	2005	ALL	Body	Body Control Module	V	V																		V	V																																					
Z	2005	ALL	Body	Digital Radio Receiver	V	V																			V																																					
Z	2005	ALL	Body	HVAC Control Module	V	V																		V	V																																					
Z	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																					
Z	2005	ALL	Body	Radio	V																																																							
Z	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																					
Z	2005	ALL	Body	Theft Deterrent Module	V	V																			V																																					
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V																
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module	V	V																		V											V	V																									
Z	2006	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module	V	V	V						V			V		V			V	V		V	V																					V														
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V	V	V		V				V			V		V	V		V	V		V	V																					V														
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module	V	V																		V											V	V																									
Z	2006	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
Z	2006	ALL	Chassis	Power Steering Control Module	V	V																		V																																					
Z	2006	ALL	Body	Body Control Module	V	V																		V	V																																					
Z	2006	ALL	Body	Digital Radio Receiver	V	V																			V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Z	2006	ALL	Body	HVAC Control Module	V	V																		V	V																																			
Z	2006	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
Z	2006	ALL	Body	Radio	V																																																						
Z	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
Z	2006	ALL	Body	Theft Deterrent Module	V	V																			V																																			
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module	V	V																		V										V	V																									
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V	V	V		V				V			V		V	V		V	V		V	V																				V														
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module	V	V																		V										V	V																									
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V	V	V		V				V			V		V	V		V	V		V	V																				V														
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module	V	V																		V										V	V																									
Z	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
Z	2007	ALL	Chassis	Power Steering Control Module	V	V																		V																																				
Z	2007	ALL	Body	Body Control Module	V	V																		V	V																																			
Z	2007	ALL	Body	Digital Radio Receiver	V	V																			V																																			
Z	2007	ALL	Body	Disc Player and Video Display	V	V																			V																																			
Z	2007	ALL	Body	HVAC Control Module	V	V																		V	V																																			
Z	2007	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
Z	2007	ALL	Body	Radio	V																																																						
Z	2007	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
Z	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
Z	2007	ALL	Body	Theft Deterrent Module	V	V																			V																																			
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module	V	V																		V										V	V																									
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed	V	V																		V										V	V																									
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V	V	V		V				V			V		V	V		V	V		V	V																				V														
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module	V	V																		V										V	V																									
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V			V		V	V		V	V																				V														
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V	V																							
Z	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
Z	2008	ALL	Chassis	Power Steering Control Module	V	V																		V																																				
Z	2008	ALL	Body	Body Control Module Classic	V	V																		V	V																																			
Z	2008	ALL	Body	Body Control Module Malibu	V	V																		V	V																																			
Z	2008	ALL	Body	Digital Radio Receiver	V	V																			V																																			
Z	2008	ALL	Body	Disc Player and Video Display	V	V																			V																																			
Z	2008	ALL	Body	HVAC Control Module Classic	V	V																		V	V																																			
Z	2008	ALL	Body	HVAC Control Module Malibu	V	V																		V	V																																			
Z	2008	ALL	Body	Instrument Panel Cluster Classic	V	V																		V	V																																			
Z	2008	ALL	Body	Instrument Panel Cluster Malibu	V	V																		V	V																																			
Z	2008	ALL	Body	Radio	V	V																		V	V																																			
Z	2008	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
Z	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
Z	2008	ALL	Body	Theft Deterrent Module	V	V																			V																																			
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed	V	V																		V										V	V																									
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump	V	V	V		V				V			V		V	V		V	V		V	V																				V														
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump	V	V	V		V				V			V		V	V		V	V		V	V																				V														
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift	V	V																		V										V	V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Without Tap Shift	V	V																		V										V	V																									
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V	V	V		V				V			V		V	V		V	V		V	V																				V													
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module	V	V																		V										V	V																								
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V			V		V	V		V	V																				V													
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V	V																							
Z	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
Z	2009	ALL	Chassis	Power Steering Control Module	V	V																		V																																			
Z	2009	ALL	Body	Body Control Module	V	V																		V	V																																		
Z	2009	ALL	Body	Digital Radio Receiver	V	V																			V																																		
Z	2009	ALL	Body	Disc Player and Video Display	V	V																			V																																		
Z	2009	ALL	Body	HVAC Control Module	V	V																		V	V																																		
Z	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
Z	2009	ALL	Body	Personal Audio Link Module	V																			V	V																																		
Z	2009	ALL	Body	Radio	V	V																		V	V																																		
Z	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
Z	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																		
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed	V	V																		V										V	V																							
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 4 Speed	V	V																		V										V	V																							
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V	V	V		V				V			V		V	V		V	V		V	V																				V													
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module	V	V																		V										V	V																							
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V	V	V		V				V			V		V	V		V	V		V	V																				V													
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module	V	V																		V										V	V																							
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V			V		V	V		V	V																				V													
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V	V																							
Z	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
Z	2010	ALL	Chassis	Power Steering Control Module	V	V																		V																																			
Z	2010	ALL	Body	Body Control Module	V	V																		V	V																																		
Z	2010	ALL	Body	Digital Radio Receiver	V	V																			V																																		
Z	2010	ALL	Body	HVAC Control Module	V	V																		V	V																																		
Z	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
Z	2010	ALL	Body	Personal Audio Link Module	V																			V	V																																		
Z	2010	ALL	Body	Radio	V	V																		V	V																																		
Z	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
Z	2010	ALL	Body	Theft Deterrent Module	V	V																			V																																		
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module	V	V																		V										V	V	V																							
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Transmission Control Module	V	V																		V										V	V	V																							
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V			V		V	V		V	V																				V													
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V	V																							
Z	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
Z	2011	ALL	Chassis	Power Steering Control Module	V	V																		V																																			
Z	2011	ALL	Body	Body Control Module	V	V																		V	V																																		
Z	2011	ALL	Body	Digital Radio Receiver	V	V																			V																																		
Z	2011	ALL	Body	HVAC Control Module	V	V																		V	V																																		
Z	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
Z	2011	ALL	Body	Personal Audio Link Module	V																			V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Z	2011	ALL	Body	Radio	V	V																		V	V																																			
Z	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
Z	2011	ALL	Body	Theft Deterrent Module	V	V																			V																																			
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																			V															
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Transmission Control Module	V	V																		V										V	V	V																							
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																			V															
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Transmission Control Module	V	V																		V										V	V	V																							
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																			V															
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Transmission Control Module	V	V																		V										V	V	V																							
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V			V		V	V		V	V																			V															
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V	V																							
Z	2012	Malibu (Seventh Gen)	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
Z	2012	Malibu (Seventh Gen)	Chassis	Power Steering Control Module	V	V																		V																																			
Z	2012	Malibu (Seventh Gen)	Body	Body Control Module	V	V																		V	V																																		
Z	2012	Malibu (Seventh Gen)	Body	Digital Radio Receiver	V	V																			V																																		
Z	2012	Malibu (Seventh Gen)	Body	HVAC Control Module	V	V																		V	V																																		
Z	2012	Malibu (Seventh Gen)	Body	Instrument Panel Cluster	V	V																		V	V																																		
Z	2012	Malibu (Seventh Gen)	Body	Personal Audio Link Module	V																			V	V																																		
Z	2012	Malibu (Seventh Gen)	Body	Radio	V	V																		V	V																																		
Z	2012	Malibu (Seventh Gen)	Body	Supplemental Inflatable Restraint	V	V																			V																																		
Z	2012	Malibu (Seventh Gen)	Body	Theft Deterrent Module	V	V																			V																																		
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Fuel Injector Control Module		V									V					V				V	V																																		
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Automatic Transmission	V																			V	V																																		
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Manual Transmission	V																			V	V																																		
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Transmission Control Module	V	V																		V	V										V		V																						
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Fuel Pump Control Module	V	V																		V	V							V		V																									
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V											V																
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Fuel Pump Control Module	V	V																		V	V							V		V																									
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V														
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V	V						V	V	V	V	V	V														
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
Z	2012	Malibu (Eighth Gen)	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																							V											
Z	2012	Malibu (Eighth Gen)	Chassis	Electronic Brake Control Module	V	V																		V	V												V												V	V	V	V	V	V						
Z	2012	Malibu (Eighth Gen)	Chassis	Parking Brake Control Module	V	V																			V																						V								V	V	V	V		
Z	2012	Malibu (Eighth Gen)	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
Z	2012	Malibu (Eighth Gen)	Chassis	Power Steering Control Module	V	V																			V																																		
Z	2012	Malibu (Eighth Gen)	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
Z	2012	Malibu (Eighth Gen)	Chassis	Suspension Control Module	V	V																		V	V																																		
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																		
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3	V	V																		V	V																																		
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4	V	V																		V	V																																		
Z	2012	Malibu (Eighth Gen)	Body	Passenger Presence Module	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Z	2012	Malibu (Eighth Gen)	Body	Instrument Cluster	V	V																		V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	Head-Up Display Module	V																			V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	Headlamp Control Module	V	V																		V	V																							V												
Z	2012	Malibu (Eighth Gen)	Body	Radio	V	V																		V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	Digital Radio Receiver Control Module	V	V																			V																																				
Z	2012	Malibu (Eighth Gen)	Body	Multimedia Player Interface Module	V	V																			V																																				
Z	2012	Malibu (Eighth Gen)	Body	Mobile Telephone Control Module	V	V																		V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Dual (CJ2)	V	V																		V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	Rear Seat Heating Control Module	V	V																		V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	Keyless Entry Control Module	V	V																		V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	Right Side Object Detection Control Module	V	V																		V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	Left Side Object Detection Control Module	V	V																		V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	Parking Assist Control Module	V																			V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	Vehicle Direction Camera Control Module	V	V																		V	V																																				
Z	2012	Malibu (Eighth Gen)	Body	Steering Column Lock Control Module	V	V																			V																																				
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Engine Control Module	V																			V	V				V	V	V	V	V												V	V														
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Engine Control Module	V																			V	V			V	V	V	V	V																												
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 1		V																			V																																				
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 2		V																			V																																				
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module	V																			V	V				V	V	V	V	V												V															
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 6 Speed (MNM)	V	V																		V	V									V	V	V	V	V	V																				
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 8 Speed (MRC)	V	V																		V	V									V	V	V	V																						
Z	2016	Malibu	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V				V		
Z	2016	Malibu	Chassis	Brake Booster Control Module	V	V																			V																																			
Z	2016	Malibu	Chassis	Power Steering Control Module	V	V																			V																																			
Z	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
Z	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
Z	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
Z	2016	Malibu	Body	Passenger Presence Module	V	V																			V																																			
Z	2016	Malibu	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V																			V	V																																			
Z	2016	Malibu	Body	Instrument Cluster Enhanced Monochrome Driver Info Center (UDC)	V																			V	V																																			
Z	2016	Malibu	Body	Radio Controls	V																				V																																			
Z	2016	Malibu	Body	HVAC Controls	V																			V	V																																			
Z	2016	Malibu	Body	Active Safety Control Module	V	V																		V	V																					V															
Z	2016	Malibu	Body	Headlamp Control Module	V	V																		V	V																					V															
Z	2016	Malibu	Body	Radio Base	V	V																		V	V																																			
Z	2016	Malibu	Body	Radio (IOA)	V	V																		V	V																																			
Z	2016	Malibu	Body	Radio Uplevel (IO4 IO5 IO6)	V	V																		V	V																																			
Z	2016	Malibu	Body	Amplifier	V	V																			V																																			
Z	2016	Malibu	Body	Human Machine Interface Control Module	V	V																		V	V																					V															
Z	2016	Malibu	Body	Navigation Control Module	V	V																			V																																			
Z	2016	Malibu	Body	Mobile Telephone Control Module	V	V																		V	V																																			
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
Z	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)	V	V																		V	V																																			
Z	2016	Malibu	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
Z	2016	Malibu	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
Z	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
Z	2016	Malibu	Body	Electric A/C Compressor Control Module																					V																																			
Z	2016	Malibu	Body	Seat Memory Control Module - Driver	V																																																							
Z	2016	Malibu	Body	Keyless Entry Control Module	V	V																	V	V																																			
Z	2016	Malibu	Body	Right Side Object Detection Control Module	V																		V	V																																			
Z	2016	Malibu	Body	Left Side Object Detection Control Module	V																		V	V																																			
Z	2016	Malibu	Body	Parking Assist Control Module	V																		V	V																																			
Z	2016	Malibu	Body	Frontview Camera Module	V	V																	V	V																																			
Z	2016	Malibu	Body	Frontview Camera Module	V	V																		V																																			
Z	2016	Malibu	Body	Steering Column Lock Control Module	V	V																		V																																			
Z	2016	Malibu	Body	Long Range Radar Sensor Module	V	V																		V																																			
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission	V																		V	V				V	V	V	V														V													
1	2013	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module	V	V									V					V			V	V																																			
1	2013	Malibu	Powertrain	2.0L LBN Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission	V																		V	V																																			
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission	V																		V	V																																			
1	2013	Malibu	Powertrain	2.0L LBS Transmission Control Module	V	V																	V	V										V			V																						
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Automatic Transmission	V																		V	V																																			
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Manual Transmission	V																		V	V																																			
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission	V																		V	V				V	V	V	V														V													
1	2013	Malibu	Powertrain	2.0L LTD Fuel Pump Control Module	V	V																	V	V							V		V																									
1	2013	Malibu	Powertrain	2.0L LTD Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission	V																		V	V	V	V		V	V	V	V	V													V													
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission	V																		V	V	V	V		V	V	V	V													V	V													
1	2013	Malibu	Powertrain	(X) 2.0L LTG Fuel Pump Control Module	V	V																		V																																			
1	2013	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																	V	V										V	V	V	V										V												
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V	V																												
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																		V	V			V	V	V	V	V													V														
1	2013	Malibu	Powertrain	2.4L LE9 Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
1	2013	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module	V																		V	V	V	V		V	V	V	V	V													V													
1	2013	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																		V																																			
1	2013	Malibu	Powertrain	(R) 2.4L LUK Fuel Pump Control Module	V	V									V								V	V							V																											
1	2013	Malibu	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module	V	V	V																V	V																																			
1	2013	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																		V	V	V	V		V	V	V	V	V													V													
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																		V	V	V	V	V	V	V	V	V													V													
1	2013	Malibu	Powertrain	(A) 2.5L LCV Fuel Pump Control Module	V	V																		V																																			
1	2013	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V								V	V	V	V		V													
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V								V	V	V	V	V	V													
1	2013	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
1	2013	Malibu	Chassis	Electronic Brake Control Module	V	V																	V	V													V									V	V	V	V	V	V						
1	2013	Malibu	Chassis	Parking Brake Control Module	V	V																		V																					V							V	V	V	V		
1	2013	Malibu	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																	V	V
1	2013	Malibu	Chassis	Power Steering Control Module	V	V																		V																																		
1	2013	Malibu	Chassis	Steering Wheel Angle Sensor Module	V																			V																																		
1	2013	Malibu	Chassis	Suspension Control Module	V	V																	V	V																																		
1	2013	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																	V	V																																		
1	2013	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																	V	V																																		
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3	V	V																	V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4	V	V																		V	V																																			
1	2013	Malibu	Body	Passenger Presence Module	V	V																			V																																			
1	2013	Malibu	Body	Instrument Cluster	V	V																		V	V																																			
1	2013	Malibu	Body	Headlamp Control Module	V	V																		V	V																							V											
1	2013	Malibu	Body	Radio	V	V																		V	V																																			
1	2013	Malibu	Body	Digital Radio Receiver Control Module	V	V																			V																																			
1	2013	Malibu	Body	Multimedia Player Interface Module	V	V																			V																																			
1	2013	Malibu	Body	Mobile Telephone Control Module	V	V																		V	V																																			
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
1	2013	Malibu	Body	HVAC Control Module Auto Dual (CJ2)	V	V																		V	V																																			
1	2013	Malibu	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
1	2013	Malibu	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
1	2013	Malibu	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
1	2013	Malibu	Body	Keyless Entry Control Module	V	V																		V	V																																			
1	2013	Malibu	Body	Parking Assist Control Module	V																			V	V																																			
1	2013	Malibu	Body	Vehicle Direction Camera Control Module	V	V																		V	V																																			
1	2013	Malibu	Body	Steering Column Lock Control Module	V	V																			V																																			
1	2013	Malibu	Body	Battery Energy Control Module		V																			V																																			
1	2014	Impala	Powertrain	(R) 2.4L LUK Engine Control Module	V																			V	V	V	V	V	V	V	V	V	V																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
1	2014	Impala	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																			V																																			
1	2014	Impala	Powertrain	(L) 2.5L LKW Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V	V													
1	2014	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
1	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
1	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V												
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump	V	V																		V	V							V		V																									
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
1	2014	Impala	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
1	2014	Impala	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
1	2014	Impala	Chassis	Parking Brake Control Module	V	V																			V																						V						V	V	V	V		
1	2014	Impala	Chassis	Power Steering Control Module	V	V																			V																																			
1	2014	Impala	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
1	2014	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
1	2014	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
1	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
1	2014	Impala	Body	Passenger Presence Module	V	V																			V																																			
1	2014	Impala	Body	Instrument Cluster	V	V																		V	V																																			
1	2014	Impala	Body	Radio Control	V																				V																																			
1	2014	Impala	Body	HVAC Control	V																			V	V																																			
1	2014	Impala	Body	Radio	V	V																		V	V																																			
1	2014	Impala	Body	Amplifier	V	V																			V																																			
1	2014	Impala	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
1	2014	Impala	Body	HVAC Control Module	V	V																		V	V																																			
1	2014	Impala	Body	Keyless Entry Control Module	V	V																		V	V																																			
1	2014	Impala	Body	Right Side Object Detection Control Module	V																			V	V																																			
1	2014	Impala	Body	Left Side Object Detection Control Module	V																			V	V																																			
1	2014	Impala	Body	Parking Assist Control Module	V																			V	V																																			
1	2014	Impala	Body	Frontview Camera Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2014	Impala	Body	Steering Column Lock Control Module	V	V																			V																																			
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
1	2014	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module	V	V									V					V				V	V																																		
1	2014	Malibu	Powertrain	2.0L LBN Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission	V																			V	V																																		
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission	V																			V	V																																		
1	2014	Malibu	Powertrain	2.0L LBS Transmission Control Module	V	V																		V	V										V			V																				
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
1	2014	Malibu	Powertrain	2.0L LTD Chassis Control Module	V	V																		V	V							V		V																									
1	2014	Malibu	Powertrain	2.0L LTD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V												V														
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission	V																			V	V	V	V		V	V	V	V												V	V													
1	2014	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module	V	V																			V																																		
1	2014	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																		V	V										V	V	V	V									V													
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																										
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V														
1	2014	Malibu	Powertrain	2.4L LE9 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
1	2014	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V														
1	2014	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module	V	V									V									V	V							V																										
1	2014	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module		V																			V																																		
1	2014	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V												V														
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V														
1	2014	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module	V	V																			V																																		
1	2014	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V								V	V	V	V		V													
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
1	2014	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
1	2014	Malibu	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V						
1	2014	Malibu	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
1	2014	Malibu	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
1	2014	Malibu	Chassis	Power Steering Control Module	V	V																			V																																		
1	2014	Malibu	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
1	2014	Malibu	Chassis	Suspension Control Module	V	V																		V	V																																		
1	2014	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																		
1	2014	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3	V	V																		V	V																																		
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4	V	V																		V	V																																		
1	2014	Malibu	Body	Passenger Presence Module	V	V																			V																																		
1	2014	Malibu	Body	Instrument Cluster	V	V																		V	V																																		
1	2014	Malibu	Body	Headlamp Control Module	V	V																		V	V																					V														
1	2014	Malibu	Body	Radio	V	V																		V	V																																		
1	2014	Malibu	Body	Digital Radio Receiver Control Module	V	V																			V																																		
1	2014	Malibu	Body	Multimedia Player Interface Module	V	V																			V																																		
1	2014	Malibu	Body	Mobile Telephone Control Module	V	V																		V	V																																		
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
1	2014	Malibu	Body	HVAC Control Module Auto Dual (CJ2)	V	V																		V	V																																		
1	2014	Malibu	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2014	Malibu	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
1	2014	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)	V	V																		V	V																																			
1	2014	Malibu	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
1	2014	Malibu	Body	Keyless Entry Control Module	V	V																		V	V																																			
1	2014	Malibu	Body	Left Side Object Detection Control Module	V																			V	V																																			
1	2014	Malibu	Body	Parking Assist Control Module	V																			V	V																																			
1	2014	Malibu	Body	Frontview Camera Module	V	V																		V	V																																			
1	2014	Malibu	Body	Steering Column Lock Control Module	V	V																			V																																			
1	2015	Impala	Powertrain	(L) 2.5L LKW Engine Control Module	V																			V	V	V	V	V	V	V	V	V	V												V															
1	2015	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
1	2015	Impala	Powertrain	(N) 3.6L LFR Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V															
1	2015	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module	V	V																		V	V										V	V	V	V									V												
1	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
1	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V												
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump	V	V																		V	V							V		V																									
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter	V	V									V									V	V							V																											
1	2015	Impala	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
1	2015	Impala	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
1	2015	Impala	Chassis	Parking Brake Control Module	V	V																			V																						V						V	V	V	V		
1	2015	Impala	Chassis	Power Steering Control Module	V	V																			V																																		
1	2015	Impala	Chassis	Power Steering Control Module	V	V																			V																																		
1	2015	Impala	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
1	2015	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																		
1	2015	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
1	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
1	2015	Impala	Body	Passenger Presence Module	V	V																			V																																		
1	2015	Impala	Body	Instrument Cluster	V	V																		V	V																																		
1	2015	Impala	Body	Radio Control	V																				V																																		
1	2015	Impala	Body	HVAC Control	V																			V	V																																		
1	2015	Impala	Body	Radio	V	V																		V	V																																		
1	2015	Impala	Body	Amplifier	V	V																			V																																		
1	2015	Impala	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
1	2015	Impala	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
1	2015	Impala	Body	HVAC Control Module	V	V																		V	V																																		
1	2015	Impala	Body	Keyless Entry Control Module	V	V																		V	V																																		
1	2015	Impala	Body	Right Side Object Detection Control Module	V																			V	V																																		
1	2015	Impala	Body	Left Side Object Detection Control Module	V																			V	V																																		
1	2015	Impala	Body	Parking Assist Control Module	V																			V	V																																		
1	2015	Impala	Body	Frontview Camera Module	V	V																		V	V																																		
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
1	2015	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module	V	V									V					V				V	V																																		
1	2015	Malibu	Powertrain	2.0L LBN Chassis Control Module	V	V																			V																																		
1	2015	Malibu	Powertrain	2.0L LBN Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission	V																			V	V																																		
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission	V																			V	V																																		
1	2015	Malibu	Powertrain	2.0L LBS Chassis Control Module	V	V																			V																																		
1	2015	Malibu	Powertrain	2.0L LBS Transmission Control Module	V	V																		V	V										V			V																					
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
1	2015	Malibu	Powertrain	2.0L LTD Chassis Control Module	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2015	Malibu	Powertrain	2.0L LTD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V													V													
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission	V																			V	V	V	V		V	V	V	V													V	V													
1	2015	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module	V	V																			V																																		
1	2015	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																		V	V									V	V	V	V									V													
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V												V														
1	2015	Malibu	Powertrain	2.4L LE9 Chassis Control Module	V	V																			V																																	
1	2015	Malibu	Powertrain	2.4L LE9 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
1	2015	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module	V																			V	V	V	V		V	V	V	V	V												V													
1	2015	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module	V	V																			V																																	
1	2015	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V	V	V		V	V	V	V	V												V													
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V														
1	2015	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module	V	V																			V																																	
1	2015	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V													
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
1	2015	Malibu	Powertrain	3.0L LFW Chassis Control Module	V	V																			V																																	
1	2015	Malibu	Powertrain	3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
1	2015	Malibu	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V											
1	2015	Malibu	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V					
1	2015	Malibu	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V	
1	2015	Malibu	Chassis	Power Steering Control Module	V	V																			V																																	
1	2015	Malibu	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
1	2015	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																	
1	2015	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																	
1	2015	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
1	2015	Malibu	Body	Passenger Presence Module	V	V																			V																																	
1	2015	Malibu	Body	Instrument Cluster	V	V																		V	V																																	
1	2015	Malibu	Body	Headlamp Control Module	V	V																		V	V																						V											
1	2015	Malibu	Body	Radio	V	V																		V	V																																	
1	2015	Malibu	Body	Digital Radio Receiver Control Module	V	V																			V																																	
1	2015	Malibu	Body	Multimedia Player Interface Module	V	V																			V																																	
1	2015	Malibu	Body	Mobile Telephone Control Module	V	V																		V	V																																	
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																	
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
1	2015	Malibu	Body	HVAC Control Module Auto Dual (CJ2)	V	V																		V	V																																	
1	2015	Malibu	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																	
1	2015	Malibu	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																	
1	2015	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)	V	V																		V	V																																	
1	2015	Malibu	Body	Front Seat Heating Control Module	V	V																		V	V																																	
1	2015	Malibu	Body	Rear Seat Heating Control Module	V	V																		V	V																																	
1	2015	Malibu	Body	Keyless Entry Control Module	V	V																		V	V																																	
1	2015	Malibu	Body	Left Side Object Detection Control Module	V																			V	V																																	
1	2015	Malibu	Body	Parking Assist Control Module	V	V																		V	V																																	
1	2015	Malibu	Body	Frontview Camera Module	V	V																		V	V																																	
1	2015	Malibu	Body	Steering Column Lock Control Module	V	V																			V																																	
1	2015	Malibu (LSG)	Powertrain	1.6L LLU Engine Control Module	V																			V	V					V	V													V															
1	2015	Malibu (LSG)	Powertrain	Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
1	2015	Malibu (LSG)	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V											

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2015	Malibu (LSG)	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
1	2015	Malibu (LSG)	Chassis	Parking Brake Control Module	V	V																			V																					V						V	V	V	V		
1	2015	Malibu (LSG)	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
1	2015	Malibu (LSG)	Chassis	Suspension Control Module	V	V																		V	V																																	
1	2015	Malibu (LSG)	Body	Body Control Module	V	V																		V	V																																	
1	2015	Malibu (LSG)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
1	2015	Malibu (LSG)	Body	Instrument Cluster	V	V																		V	V																																	
1	2015	Malibu (LSG)	Body	Headlamp Control Module	V	V																		V	V																						V											
1	2015	Malibu (LSG)	Body	Radio	V	V																		V	V																																	
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																	
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
1	2015	Malibu (LSG)	Body	HVAC Control Module	V	V																		V	V																																	
1	2015	Malibu (LSG)	Body	Front Seat Heating Control Module	V	V																		V	V																																	
1	2015	Malibu (LSG)	Body	Keyless Entry Control Module	V	V																		V	V																																	
1	2015	Malibu (LSG)	Body	Left Side Object Detection Control Module	V																			V	V																																	
1	2015	Malibu (LSG)	Body	Parking Assist Control Module	V																			V	V																																	
1	2015	Malibu (LSG)	Body	Frontview Camera Module	V	V																		V	V																																	
1	2015	Malibu (LSG)	Body	Steering Column Lock Control Module	V	V																			V																																	
1	2016	Impala	Powertrain	(A) 2.5L LCV Engine Control Module	V																			V	V	V	V	V	V	V	V	V																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
1	2016	Impala	Powertrain	(N) 3.6L LFR Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V													
1	2016	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module	V	V																		V	V									V	V	V	V									V											
1	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V											
1	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V											
1	2016	Impala	Powertrain	Chassis Control Module	V	V									V									V	V							V																									
1	2016	Impala	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
1	2016	Impala	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																	
1	2016	Impala	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
1	2016	Impala	Chassis	Power Steering Control Module	V	V																			V																																	
1	2016	Impala	Chassis	Power Steering Control Module	V	V																			V																																	
1	2016	Impala	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
1	2016	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																	
1	2016	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																	
1	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
1	2016	Impala	Body	Passenger Presence Module	V	V																			V																																	
1	2016	Impala	Body	Instrument Cluster	V	V																		V	V																																	
1	2016	Impala	Body	Radio Control	V																				V																																	
1	2016	Impala	Body	HVAC Control	V																			V	V																																	
1	2016	Impala	Body	Radio	V	V																		V	V																																	
1	2016	Impala	Body	Amplifier	V	V																			V																																	
1	2016	Impala	Body	Human Machine Interface Control Module	V	V																		V	V																					V													
1	2016	Impala	Body	Navigation Control Module	V	V																			V																																	
1	2016	Impala	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
1	2016	Impala	Body	HVAC Control Module	V	V																		V	V																																	
1	2016	Impala	Body	Seat Memory Control Module - Driver	V																																																				
1	2016	Impala	Body	Keyless Entry Control Module	V	V																		V	V																																	
1	2016	Impala	Body	Right Side Object Detection Control Module	V																			V	V																																	
1	2016	Impala	Body	Left Side Object Detection Control Module	V																			V	V																																	
1	2016	Impala	Body	Parking Assist Control Module	V																			V	V																																	
1	2016	Impala	Body	Frontview Camera Module	V	V																		V	V																																	
1	2016	Malibu	Powertrain	2.0L LTD Engine Control Module	V																			V	V				V	V	V	V												V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V	V																													
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																		V	V			V	V	V	V	V													V															
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																		V	V	V	V	V	V	V	V	V	V																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																		V	V	V	V	V	V	V	V	V												V															
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
1	2016	Malibu	Powertrain	Fuel Injector Control Module	V	V																	V	V													V										V	V	V	V	V	V				V		
1	2016	Malibu	Powertrain	Chassis Control Module	V	V																	V	V																																		
1	2016	Malibu	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V						
1	2016	Malibu	Chassis	Parking Brake Control Module	V	V																		V																					V								V	V	V	V		
1	2016	Malibu	Chassis	Power Steering Control Module	V	V																		V																																		
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module	V																			V																																		
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																	V	V																																		
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																	V	V																																		
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
1	2016	Malibu	Body	Passenger Presence Module	V	V																		V																																		
1	2016	Malibu	Body	Instrument Cluster	V	V																	V	V																																		
1	2016	Malibu	Body	Headlamp Control Module	V	V																	V	V																						V													
1	2016	Malibu	Body	Radio	V	V																	V	V																																		
1	2016	Malibu	Body	Digital Radio Receiver Control Module	V	V																		V																																		
1	2016	Malibu	Body	Multimedia Player Interface Module	V	V																		V																																		
1	2016	Malibu	Body	Mobile Telephone Control Module	V	V																	V	V																																		
1	2016	Malibu	Body	Telematics Communication Interface Control Module	V	V																	V	V																																		
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)	V	V																	V	V																																		
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)	V	V																	V	V																																		
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)	V	V																	V	V																																		
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)	V	V																	V	V																																		
1	2016	Malibu	Body	Seat Memory Control Module	V																																																					
1	2016	Malibu	Body	Front Seat Heating Control Module	V	V																	V	V																																		
1	2016	Malibu	Body	Rear Seat Heating Control Module	V	V																	V	V																																		
1	2016	Malibu	Body	Keyless Entry Control Module	V	V																	V	V																																		
1	2016	Malibu	Body	Left Side Object Detection Control Module	V																		V	V																																		
1	2016	Malibu	Body	Parking Assist Control Module	V																		V	V																																		
1	2016	Malibu	Body	Frontview Camera Module	V	V																	V	V																																		

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2005	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																										
A	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
A	2005	ALL	Powertrain	Transmission Control Module																																																										
A	2005	ALL	Chassis	Power Steering Control Module																																																										
A	2005	ALL	Chassis	Anti-lock Brake System																																																										
A	2005	ALL	Body	Body Control Module																																																										
A	2005	ALL	Body	Digital Radio Receiver																																																										
A	2005	ALL	Body	Instrument Panel																																																										
A	2005	ALL	Body	Radio																																																										
A	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2006	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																										
A	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
A	2006	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																										
A	2006	ALL	Powertrain	Transmission Control Module																																																										
A	2006	ALL	Chassis	Power Steering Control Module																																																										
A	2006	ALL	Chassis	Anti-lock Brake System																																																										
A	2006	ALL	Body	Body Control Module																																																										
A	2006	ALL	Body	Digital Radio Receiver																																																										
A	2006	ALL	Body	Instrument Panel																																																										
A	2006	ALL	Body	Radio																																																										
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2006	ALL	Body	Theft Deterrent Module																																																										
A	2007	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																										
A	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
A	2007	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																										
A	2007	ALL	Powertrain	Transmission Control Module																																																										
A	2007	ALL	Chassis	Power Steering Control Module																																																										
A	2007	ALL	Chassis	Electronic Brake Control Module																																																										
A	2007	ALL	Body	Body Control Module																																																										
A	2007	ALL	Body	Digital Radio Receiver																																																										
A	2007	ALL	Body	Instrument Panel Cluster																																																										
A	2007	ALL	Body	Passenger Presence System																																																										
A	2007	ALL	Body	Personal Audio Link Module																																																										
A	2007	ALL	Body	Radio																																																										
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2007	ALL	Body	Theft Deterrent Module																																																										
A	2008	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
A	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																										
A	2008	ALL	Powertrain	Transmission Control Module																																																										
A	2008	ALL	Chassis	Power Steering Control Module																																																										
A	2008	ALL	Chassis	Electronic Brake Control Module with VSES																																																										
A	2008	ALL	Chassis	Electronic Brake Control Module without VSES																																																										
A	2008	ALL	Body	Body Control Module																																																										
A	2008	ALL	Body	Digital Radio Receiver																																																										
A	2008	ALL	Body	Instrument Panel Cluster																																																										
A	2008	ALL	Body	Passenger Presence System																																																										
A	2008	ALL	Body	Personal Audio Link Module																																																										
A	2008	ALL	Body	Radio																																																										
A	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2008	ALL	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2009	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																									
A	2009	ALL	Powertrain	(H)2.2L L4 LAP Engine Control Module																																																									
A	2009	ALL	Powertrain	Transmission Control Module																																																									
A	2009	ALL	Chassis	Power Steering Control Module																																																									
A	2009	ALL	Chassis	Electronic Brake Control Module with VSES																																																									
A	2009	ALL	Chassis	Electronic Brake Control Module without VSES																																																									
A	2009	ALL	Body	Body Control Module																																																									
A	2009	ALL	Body	Digital Radio Receiver																																																									
A	2009	ALL	Body	Instrument Panel Cluster																																																									
A	2009	ALL	Body	Passenger Presence System																																																									
A	2009	ALL	Body	Personal Audio Link Module																																																									
A	2009	ALL	Body	Radio																																																									
A	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2009	ALL	Body	Theft Deterrent Module																																																									
A	2010	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																									
A	2010	ALL	Powertrain	(5)2.2L L4 LAP Engine Control Module																																																									
A	2010	ALL	Powertrain	Transmission Control Module																																																									
A	2010	ALL	Chassis	Power Steering Control Module																																																									
A	2010	ALL	Chassis	Electronic Brake Control Module with VSES																																																									
A	2010	ALL	Chassis	Electronic Brake Control Module without VSES																																																									
A	2010	ALL	Body	Body Control Module																																																									
A	2010	ALL	Body	Digital Radio Receiver																																																									
A	2010	ALL	Body	Driver Information Center																																																									
A	2010	ALL	Body	Instrument Panel Cluster																																																									
A	2010	ALL	Body	Passenger Presence System																																																									
A	2010	ALL	Body	Personal Audio Link Module																																																									
A	2010	ALL	Body	Radio																																																									
A	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2010	ALL	Body	Theft Deterrent Module																																																									
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
A	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																									
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
A	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																									
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																									
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																									
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
A	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
A	2012	Cobalt	Chassis	Electronic Brake Control Module																																																									
A	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																									
A	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
A	2012	Cobalt	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V																																				
A	2012	Cobalt	Body	Passenger Presence Module																															V																										
A	2012	Cobalt	Body	Instrument Cluster																																V																								
A	2012	Cobalt	Body	Radio																																																								
A	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																									
A	2012	Cobalt	Body	Telematics Communication Interface Control Module																																	V	V	V	V																				
A	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																											V												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V											
A	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																												V											
A	2012	Cobalt	Body	Front Seat Heating Control Module																																					V	V																		
A	2012	Cobalt	Body	Parking Assist Control Module																																V																							
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																							
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																							
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																				V																																			
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																							
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																						
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																						
A	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																						
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																				V																																			
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																						
A	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																						
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																				V																																			
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																						
A	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																						
A	2013	Cobalt	Chassis	Electronic Brake Control Module																																																						
A	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																						
A	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
A	2013	Cobalt	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V																																			
A	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
A	2013	Cobalt	Body	Instrument Cluster																																V																							
A	2013	Cobalt	Body	Radio																																																						
A	2013	Cobalt	Body	Telematics Communication Interface Control Module																																	V	V	V	V																		
A	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																												V										
A	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V										
A	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																												V										
A	2013	Cobalt	Body	Front Seat Heating Control Module																																					V	V																
A	2013	Cobalt	Body	Parking Assist Control Module																																V																						
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																						
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																						
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																				V																																			
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																						
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																						
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																						
A	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																						
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																				V																																			
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																						
A	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																						
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																				V																																			
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																						
A	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																						
A	2014	Cobalt	Chassis	Electronic Brake Control Module																																																						
A	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																						
A	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
A	2014	Cobalt	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V																																			
A	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
A	2014	Cobalt	Body	Instrument Cluster																																V																							
A	2014	Cobalt	Body	Radio																																																						
A	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																												V										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V											
A	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																												V											
A	2014	Cobalt	Body	Front Seat Heating Control Module																																					V	V																		
A	2014	Cobalt	Body	Parking Assist Control Module																																V																							
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																							
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																							
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																				V																																			
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																							
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																							
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																							
A	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																							
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																				V																																			
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																							
A	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																							
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																				V																																			
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																							
A	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																							
A	2015	Cobalt	Chassis	Electronic Brake Control Module																																																							
A	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
A	2015	Cobalt	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																																			
A	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
A	2015	Cobalt	Body	Instrument Cluster																																V																							
A	2015	Cobalt	Body	Radio																																																						
A	2015	Cobalt	Body	Telematics Communication Interface Control Module																																	V	V	V																			
A	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																											V											
A	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V											
A	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																											V											
A	2015	Cobalt	Body	Front Seat Heating Control Module																																					V	V																		
A	2015	Cobalt	Body	Parking Assist Control Module																																V																							
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																							
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																							
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																				V																																			
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																							
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																							
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																							
A	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																							
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																				V																																			
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																							
A	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																							
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																				V																																			
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																							
A	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																							
A	2016	Cobalt	Chassis	Electronic Brake Control Module																																																							
A	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
A	2016	Cobalt	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V				V																								V							
A	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
A	2016	Cobalt	Body	Instrument Cluster																																V																							
A	2016	Cobalt	Body	Radio Other																																																							
A	2016	Cobalt	Body	Radio (IOB)																																																							
A	2016	Cobalt	Body	Radio (UF7)																																																							
A	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																											V											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V											
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																												V											
A	2016	Cobalt	Body	Front Seat Heating Control Module																																					V	V																		
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																							
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																							
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module																																																							
B	2010	Beat	Powertrain	Transmission Control Module																																																							
B	2010	Beat	Chassis	Electronic Brake Control Module																																																							
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																							
B	2010	Beat	Chassis	Power Steering Control Module																																																							
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																											
B	2010	Beat	Body	Instrument Cluster																																																							
B	2010	Beat	Body	Keyless Entry Control Module																																																							
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																							
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																							
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module																																																							
B	2011	Beat	Powertrain	Transmission Control Module																																																							
B	2011	Beat	Chassis	Electronic Brake Control Module																																																							
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																							
B	2011	Beat	Chassis	Electric Power Steering Control Module																																																							
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																											
B	2011	Beat	Body	Instrument Cluster																																																						
B	2011	Beat	Body	Keyless Entry Control Module																																																						
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module																																																						
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module																																																						
B	2012	Beat	Powertrain	Transmission Control Module																																																						
B	2012	Beat	Chassis	Electronic Brake Control Module																																																						
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																						
B	2012	Beat	Chassis	Electric Power Steering Control Module																																																						
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																											
B	2012	Beat	Body	Instrument Cluster																																																						
B	2012	Beat	Body	Keyless Entry Control Module																																																						
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module																																																							
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module																																																							
B	2013	Beat	Powertrain	Transmission Control Module																																																							
B	2013	Beat	Chassis	Electronic Brake Control Module																																																							
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																							
B	2013	Beat	Chassis	Electric Power Steering Control Module																																																							
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																											
B	2013	Beat	Body	Instrument Cluster																																																						
B	2013	Beat	Body	Keyless Entry Control Module																																																						
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module																																																						
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module																																																						
B	2014	Beat	Powertrain	Transmission Control Module																																																						
B	2014	Beat	Powertrain	Fuel Injector Control Module																																																						
B	2014	Beat	Chassis	Electronic Brake Control Module																																																						
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
B	2014	Beat	Chassis	Power Steering Control Module																																																								
B	2014	Beat	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
B	2014	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																											
B	2014	Beat	Body	Instrument Cluster																																																							
B	2014	Beat	Body	Telematics Communication Interface Control Module																																V	V	V																					
B	2015	Beat	Powertrain	1.0L LEB Engine Control Module																																																							
B	2015	Beat	Powertrain	1.19L LC5 Engine Control Module																																																							
B	2015	Beat	Powertrain	Transmission Control Module																																																						
B	2015	Beat	Powertrain	Fuel Injector Control Module																																																						
B	2015	Beat	Chassis	Electronic Brake Control Module																																																						
B	2015	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																						
B	2015	Beat	Chassis	Power Steering Control Module																																																						
B	2015	Beat	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
B	2015	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																											
B	2015	Beat	Body	Instrument Cluster																																																						
B	2015	Beat	Body	Radio																																																						
B	2015	Beat	Body	Telematics Communication Interface Control Module																																V	V	V																					
B	2015	Beat	Body	Keyless Entry Control Module																																																						
B	2016	Beat	Powertrain	1.0L LEB Engine Control Module																																																						
B	2016	Beat	Powertrain	1.19L LC5 Engine Control Module																																																						
B	2016	Beat	Powertrain	Transmission Control Module																																																						
B	2016	Beat	Chassis	Electronic Brake Control Module																																																						
B	2016	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																						
B	2016	Beat	Chassis	Power Steering Control Module			V																																																			
B	2016	Beat	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
B	2016	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																											
B	2016	Beat	Body	Instrument Cluster																																																						
B	2016	Beat	Body	Radio																																																						
B	2016	Beat	Body	Telematics Communication Interface Control Module																																V	V	V																					
B	2016	Beat	Body	HVAC Control Module																													V														V	V		V									
B	2016	Beat	Body	Keyless Entry Control Module																																																						
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																				V																																			
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																						
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																						
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																				V																																		
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																					
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																				V																																		
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																					
B	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																					
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																				V																																		
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																					
B	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																					
B	2016	Cruze	Chassis	Electronic Brake Control Module					V																																																	
B	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																						
B	2016	Cruze	Chassis	Power Steering Control Module	V	V	V																																																			
B	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
B	2016	Cruze	Body	Body Control Module						V	V	V		V	V		V	V	V		V	V	V	V	V		V	V																							V						
B	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V	V																								
B	2016	Cruze	Body	Passenger Presence Module																															V																							
B	2016	Cruze	Body	Instrument Cluster																																	V																				
B	2016	Cruze	Body	Radio Controls																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
B	2016	Cruze	Body	HVAC Controls																																																								
B	2016	Cruze	Body	Trailer Interface Control Module																																V																								
B	2016	Cruze	Body	Radio Base (IO3 IO7)																																																								
B	2016	Cruze	Body	Radio (IOA)																																																								
B	2016	Cruze	Body	Radio (IOB)																																																								
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																								
B	2016	Cruze	Body	Amplifier																																																								
B	2016	Cruze	Body	Multimedia Player Interface Module																																V																								
B	2016	Cruze	Body	Human Machine Interface Control Module																																																								
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																														V													V	V	V	V								
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																														V													V	V	V	V								
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																														V													V	V	V									
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																														V													V	V	V	V								
B	2016	Cruze	Body	Keyless Entry Control Module																																																								
B	2016	Cruze	Body	Right Side Object Detection Control Module																																																								
B	2016	Cruze	Body	Left Side Object Detection Control Module																																																								
B	2016	Cruze	Body	Parking Assist Control Module																																V																								
B	2016	Cruze	Body	Frontview Camera Module																																																								
B	2016	Cruze	Body	Steering Column Lock Control Module																																																								
B	2016	Cruze	Body	Long Range Radar Sensor Module																																																								
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
C	2010	Spark	Powertrain	Transmission Control Module																																																								
C	2010	Spark	Chassis	Electronic Brake Control Module																																																								
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
C	2010	Spark	Chassis	Electric Power Steering Control Module																																																								
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																									
C	2010	Spark	Body	Passenger Presence Module																																V																								
C	2010	Spark	Body	Instrument Cluster																																																								
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																								
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																								
C	2011	Spark	Powertrain	Transmission Control Module																																																								
C	2011	Spark	Chassis	Electronic Brake Control Module																																																								
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
C	2011	Spark	Chassis	Electric Power Steering Control Module																																																								
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																									
C	2011	Spark	Body	Passenger Presence Module																																V																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2011	Spark	Body	Instrument Cluster																																																									
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
C	2012	Spark	Powertrain	Transmission Control Module																																																										
C	2012	Spark	Chassis	Electronic Brake Control Module																																																										
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2012	Spark	Chassis	Electric Power Steering Control Module																																																										
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V	V																											
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																											
C	2012	Spark	Body	Passenger Presence Module																															V																										
C	2012	Spark	Body	Instrument Cluster																																																									
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																										
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																				V																																					
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																				V																																					
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																										
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2013	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2013	Spark	Chassis	Electronic Brake Control Module																																																										
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2013	Spark	Chassis	Power Steering Control Module																																																										
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
C	2013	Spark	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V				V																				V					V							
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
C	2013	Spark	Body	Passenger Presence Module																															V																										
C	2013	Spark	Body	Instrument Cluster																																V																									
C	2013	Spark	Body	Radio																																																									
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																			
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																									
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																									
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																				V																																						
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																				V					
C	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																									
C	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																									
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																				V																																					
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																				V					
C	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																									
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																									
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
C	2014	Spark	Powertrain	Fuel Injector Control Module																																																									
C	2014	Spark	Chassis	Electronic Brake Control Module																																																									
C	2014	Spark	Chassis	Electronic Brake Control Module																																																									
C	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
C	2014	Spark	Chassis	Power Steering Control Module																																																									
C	2014	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
C	2014	Spark	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V				V																				V					V							
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																															
C	2014	Spark	Body	Passenger Presence Module																															V																									
C	2014	Spark	Body	Instrument Cluster																																V																							
C	2014	Spark	Body	Radio																																																							
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																		
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																		
C	2014	Spark	Body	Keyless Entry Control Module																																																							
C	2014	Spark EV	Powertrain	Engine Control Module																																																								
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module										V																																													
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																											V											
C	2014	Spark EV	Powertrain	Drive Motor Control Module																																																							
C	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																							
C	2014	Spark EV	Chassis	Electronic Brake Control Module																																																							
C	2014	Spark EV	Chassis	Parking Brake Control Module																																																							
C	2014	Spark EV	Chassis	Power Steering Control Module			V																																																				
C	2014	Spark EV	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V		V	V				V																															
C	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																							
C	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
C	2014	Spark EV	Body	Passenger Presence Module																															V																									
C	2014	Spark EV	Body	Instrument Cluster																																V																							
C	2014	Spark EV	Body	Radio																																																							
C	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
C	2014	Spark EV	Body	HVAC Control Module																														V													V	V		V							
C	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																							
C	2014	Spark EV	Body	Coolant Heater Control Module																																																							
C	2014	Spark EV	Body	Keyless Entry Control Module																																																							
C	2014	Spark EV	Body	Battery Charger Control Module																																																							
C	2014	Spark EV	Body	DC Charging Control Module																																																							
C	2014	Spark EV	Body	Battery Energy Control Module																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																									
C	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																				V																																					
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																				V																																					
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Spark	Chassis	Power Steering Control Module																																																										
C	2015	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
C	2015	Spark	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V				V																			V					V								
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																
C	2015	Spark	Body	Passenger Presence Module																																V																									
C	2015	Spark	Body	Instrument Cluster																																	V																							
C	2015	Spark	Body	Instrument Cluster																																																									
C	2015	Spark	Body	Tire Pressure Indicator Module																																																						V				
C	2015	Spark	Body	Radio																																																									
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
C	2015	Spark	Body	Keyless Entry Control Module																																																									
C	2015	Spark EV	Powertrain	Engine Control Module																																																										
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module										V																																															
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																											V													
C	2015	Spark EV	Powertrain	Drive Motor Control Module																																																									
C	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																									
C	2015	Spark EV	Chassis	Electronic Brake Control Module																																																									
C	2015	Spark EV	Chassis	Parking Brake Control Module																																																									
C	2015	Spark EV	Chassis	Power Steering Control Module			V																																																						
C	2015	Spark EV	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V		V	V				V																			V													
C	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																									
C	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
C	2015	Spark EV	Body	Passenger Presence Module																																V																									
C	2015	Spark EV	Body	Instrument Cluster																																	V																							
C	2015	Spark EV	Body	Radio																																																									
C	2015	Spark EV	Body	HVAC Control Module																														V													V	V		V										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2015	Spark EV	Body	Coolant Heater Control Module																																																										
C	2015	Spark EV	Body	Keyless Entry Control Module																																																										
C	2015	Spark EV	Body	Battery Charger Control Module																																																										
C	2015	Spark EV	Body	DC Charging Control Module																																																										
C	2015	Spark EV	Body	Battery Energy Control Module																																																										
C	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
C	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
C	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
C	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																				V																																						
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
C	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																				V																																						
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																				V																																						
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
C	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2016	Spark	Chassis	Electronic Brake Control Module																																																										
C	2016	Spark	Chassis	Electronic Brake Control Module																																																										
C	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2016	Spark	Chassis	Power Steering Control Module																																																										
C	2016	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
C	2016	Spark	Body	Body Control Module						V	V	V		V	V		V	V	V		V	V	V	V			V	V																											V							
C	2016	Spark	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V				V																					V					V							
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																										
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																										V																																
C	2016	Spark	Body	Instrument Cluster																																V																										
C	2016	Spark	Body	Instrument Cluster																																																										
C	2016	Spark	Body	Radio																																																										
C	2016	Spark	Body	Telematics Communication Interface Control Module																																	V	V	V																							
C	2016	Spark	Body	Keyless Entry Control Module																																																										
C	2016	Spark EV	Powertrain	Engine Control Module																																																										
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module										V																																																
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																												V														
C	2016	Spark EV	Powertrain	Drive Motor Control Module																																																										
C	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2016	Spark EV	Chassis	Electronic Brake Control Module																																																										
C	2016	Spark EV	Chassis	Parking Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2016	Spark EV	Chassis	Power Steering Control Module			V																																																					
C	2016	Spark EV	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V		V	V				V																							V								
C	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																							
C	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
C	2016	Spark EV	Body	Passenger Presence Module																																V																								
C	2016	Spark EV	Body	Instrument Cluster																																	V																						
C	2016	Spark EV	Body	Radio																																																							
C	2016	Spark EV	Body	Telematics Communication Interface Control Module																																		V	V	V																			
C	2016	Spark EV	Body	HVAC Control Module																														V													V	V		V							
C	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																						
C	2016	Spark EV	Body	Coolant Heater Control Module																																																						
C	2016	Spark EV	Body	Keyless Entry Control Module																																																						
C	2016	Spark EV	Body	Frontview Camera Module																																																						
C	2016	Spark EV	Body	Battery Charger Control Module																																																						
C	2016	Spark EV	Body	DC Charging Control Module																																																						
C	2016	Spark EV	Body	Battery Energy Control Module																																																						
D	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																						
D	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																						
D	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																						
D	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																						
D	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																						
D	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																						
D	2010	Spark	Powertrain	Transmission Control Module																																																						
D	2010	Spark	Chassis	Electronic Brake Control Module																																																						
D	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																						
D	2010	Spark	Chassis	Electric Power Steering Control Module																																																						
D	2010	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																									
D	2010	Spark	Body	Passenger Presence Module																																V																							
D	2010	Spark	Body	Instrument Cluster																																																						
D	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																						
D	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																						
D	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																						
D	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																						
D	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																						
D	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																						
D	2011	Spark	Powertrain	Transmission Control Module																																																						
D	2011	Spark	Chassis	Electronic Brake Control Module																																																						
D	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																						
D	2011	Spark	Chassis	Electric Power Steering Control Module																																																						
D	2011	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																									
D	2011	Spark	Body	Passenger Presence Module																																V																							
D	2011	Spark	Body	Instrument Cluster																																																						
D	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																						
D	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																						
D	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																						
D	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																						
D	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																								
D	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																								
D	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																								
D	2012	Spark	Powertrain	Transmission Control Module																																																								
D	2012	Spark	Chassis	Electronic Brake Control Module																																																								
D	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
D	2012	Spark	Chassis	Electric Power Steering Control Module																																																								
D	2012	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V	V																										
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																											
D	2012	Spark	Body	Passenger Presence Module																															V																									
D	2012	Spark	Body	Instrument Cluster																																																								
D	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
D	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																								
D	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
D	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																								
D	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																								
D	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																								
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																				V																																				
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																				V																																				
D	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																								
D	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																								
D	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																								
D	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																								
D	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
D	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
D	2013	Spark	Powertrain	Fuel Injector Control Module																																																								
D	2013	Spark	Chassis	Electronic Brake Control Module																																																								
D	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
D	2013	Spark	Chassis	Power Steering Control Module																																																								
D	2013	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
D	2013	Spark	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V				V																			V					V								
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
D	2013	Spark	Body	Passenger Presence Module																															V																									
D	2013	Spark	Body	Instrument Cluster																																V																								
D	2013	Spark	Body	Radio																																																								
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
D	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																								
D	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																								
D	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																								
D	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																								
D	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
D	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																								
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																				V																																				
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																		V						
D	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																								
D	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
D	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																								
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																				V																																			
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																								
D	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																								
D	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																								
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
D	2014	Spark	Powertrain	Fuel Injector Control Module																																																								
D	2014	Spark	Chassis	Electronic Brake Control Module																																																								
D	2014	Spark	Chassis	Electronic Brake Control Module																																																								
D	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
D	2014	Spark	Chassis	Power Steering Control Module																																																								
D	2014	Spark	Chassis	Steering Wheel Angle Sensor Module			V	V																																																				
D	2014	Spark	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V				V																				V					V						
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																															
D	2014	Spark	Body	Passenger Presence Module																															V																									
D	2014	Spark	Body	Instrument Cluster																																V																								
D	2014	Spark	Body	Radio																																																								
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
D	2014	Spark	Body	Keyless Entry Control Module																																																								
D	2014	Spark EV	Powertrain	Engine Control Module																																																								
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module										V																																														
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																											V													
D	2014	Spark EV	Powertrain	Drive Motor Control Module																																																								
D	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								
D	2014	Spark EV	Chassis	Electronic Brake Control Module																																																								
D	2014	Spark EV	Chassis	Parking Brake Control Module																																																								
D	2014	Spark EV	Chassis	Power Steering Control Module		V																																																						
D	2014	Spark EV	Body	Body Control Module						V	V	V		V	V	V	V	V		V		V	V				V																								V								
D	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
D	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
D	2014	Spark EV	Body	Passenger Presence Module																															V																									
D	2014	Spark EV	Body	Instrument Cluster																																V																								
D	2014	Spark EV	Body	Radio																																																								
D	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
D	2014	Spark EV	Body	HVAC Control Module																														V													V	V		V									
D	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																								
D	2014	Spark EV	Body	Coolant Heater Control Module																																																								
D	2014	Spark EV	Body	Keyless Entry Control Module																																																								
D	2014	Spark EV	Body	Battery Charger Control Module																																																								
D	2014	Spark EV	Body	DC Charging Control Module																																																								
D	2014	Spark EV	Body	Battery Energy Control Module																																																								
D	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																								
D	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																								
D	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																								
D	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
D	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																								
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																				V																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																									
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																				V																																					
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2015	Spark	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2015	Spark	Chassis	Power Steering Control Module																																																										
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
D	2015	Spark	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V				V																				V					V								
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																
D	2015	Spark	Body	Passenger Presence Module																																V																									
D	2015	Spark	Body	Instrument Cluster																																	V																						
D	2015	Spark	Body	Instrument Cluster																																																								
D	2015	Spark	Body	Tire Pressure Indicator Module																																																								
D	2015	Spark	Body	Radio																																																								
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																		
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																		
D	2015	Spark	Body	Keyless Entry Control Module																																																								
D	2015	Spark EV	Powertrain	Engine Control Module																																																									
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module										V																																														
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																											V												
D	2015	Spark EV	Powertrain	Drive Motor Control Module																																																								
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								
D	2015	Spark EV	Chassis	Electronic Brake Control Module																																																								
D	2015	Spark EV	Chassis	Parking Brake Control Module																																																								
D	2015	Spark EV	Chassis	Power Steering Control Module			V																																																					
D	2015	Spark EV	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V		V	V				V																									V							
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
D	2015	Spark EV	Body	Passenger Presence Module																																V																									
D	2015	Spark EV	Body	Instrument Cluster																																	V																						
D	2015	Spark EV	Body	Radio																																																								
D	2015	Spark EV	Body	HVAC Control Module																															V												V	V		V									
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																								
D	2015	Spark EV	Body	Coolant Heater Control Module																																																								
D	2015	Spark EV	Body	Keyless Entry Control Module																																																								
D	2015	Spark EV	Body	Battery Charger Control Module																																																								
D	2015	Spark EV	Body	DC Charging Control Module																																																								
D	2015	Spark EV	Body	Battery Energy Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
D	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																				V																																					
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																				V																																					
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																				V																																					
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2016	Spark	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2016	Spark	Chassis	Power Steering Control Module																																																										
D	2016	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
D	2016	Spark	Body	Body Control Module						V	V	V		V	V		V	V	V		V	V	V	V			V	V																										V						
D	2016	Spark	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V				V																				V					V						
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																
D	2016	Spark	Body	Instrument Cluster																																V																									
D	2016	Spark	Body	Instrument Cluster																																																									
D	2016	Spark	Body	Radio																																																									
D	2016	Spark	Body	Telematics Communication Interface Control Module																																	V	V	V																					
D	2016	Spark	Body	Keyless Entry Control Module																																																									
D	2016	Spark EV	Powertrain	Engine Control Module																																																										
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module										V																																															
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																											V													
D	2016	Spark EV	Powertrain	Drive Motor Control Module																																																									
D	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																									
D	2016	Spark EV	Chassis	Electronic Brake Control Module																																																									
D	2016	Spark EV	Chassis	Parking Brake Control Module																																																									
D	2016	Spark EV	Chassis	Power Steering Control Module			V																																																						
D	2016	Spark EV	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V		V	V				V																										V						
D	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																									
D	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
D	2016	Spark EV	Body	Passenger Presence Module																																V																									
D	2016	Spark EV	Body	Instrument Cluster																																	V																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2016	Spark EV	Body	Radio																																																								
D	2016	Spark EV	Body	Telematics Communication Interface Control Module																																		V	V	V																				
D	2016	Spark EV	Body	HVAC Control Module																														V													V	V		V										
D	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																								
D	2016	Spark EV	Body	Coolant Heater Control Module																																																								
D	2016	Spark EV	Body	Keyless Entry Control Module																																																								
D	2016	Spark EV	Body	Frontview Camera Module																																																								
D	2016	Spark EV	Body	Battery Charger Control Module																																																								
D	2016	Spark EV	Body	DC Charging Control Module																																																								
D	2016	Spark EV	Body	Battery Energy Control Module																																																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Automatic Transmission																																																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Manual Transmission																																																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Transmission Control Module																																																								
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																				V																																				
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2010	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																								
F	2010	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																								
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																				V																																				
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																								
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2010	Camaro	Chassis	Electronic Brake Control Module					V																																																			
F	2010	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																								
F	2010	Camaro	Chassis	Power Steering Control Module			V																																																					
F	2010	Camaro	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
F	2010	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V																																	
F	2010	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V																																	
F	2010	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
F	2010	Camaro	Body	Passenger Presence Module																															V																									
F	2010	Camaro	Body	Instrument Cluster																																V																								
F	2010	Camaro	Body	Auxiliary Gage Module																																																								
F	2010	Camaro	Body	Radio																																																								
F	2010	Camaro	Body	Multimedia Player Interface Module																																V																								
F	2010	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																								
F	2010	Camaro	Body	Mobile Telephone Control Module																																V																								
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
F	2010	Camaro	Body	Remote Heater and Air Conditioning Control Module																														V													V	V	V	V	V									
F	2010	Camaro	Body	Front Seat Heating Control Module																																					V	V																		
F	2010	Camaro	Body	Folding Top Control Module																																																								
F	2010	Camaro	Body	Parking Assist Control Module																																V																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Automatic Transmission																																																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Manual Transmission																																																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																				V																																				
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2011	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																								
F	2011	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																								
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																				V																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																								
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2011	Camaro	Chassis	Electronic Brake Control Module					V																																																			
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																								
F	2011	Camaro	Chassis	Power Steering Control Module			V																																																					
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V																																	
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V																																
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
F	2011	Camaro	Body	Passenger Presence Module																																V																								
F	2011	Camaro	Body	Instrument Cluster																																	V																							
F	2011	Camaro	Body	Head-Up Display Module																																																								
F	2011	Camaro	Body	Auxiliary Gage Module																																																								
F	2011	Camaro	Body	Headlamp Control Module																																																								
F	2011	Camaro	Body	Radio																																																								
F	2011	Camaro	Body	Multimedia Player Interface Module																																	V																							
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																								
F	2011	Camaro	Body	Mobile Telephone Control Module																																	V																							
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module																															V												V	V	V	V	V									
F	2011	Camaro	Body	Front Seat Heating Control Module																																						V	V																	
F	2011	Camaro	Body	Folding Top Control Module																																																								
F	2011	Camaro	Body	Parking Assist Control Module																																	V																							
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																				
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																								
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																				V																																				
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																								
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																								
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																				V																																				
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																								
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																								
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																								
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module																																																								
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																								
F	2012	Camaro	Chassis	Electronic Brake Control Module					V																																																			
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																								
F	2012	Camaro	Chassis	Power Steering Control Module			V																																																					
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
F	2012	Camaro	Chassis	Suspension Control Module																																																								
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V		V	V		V	V	V	V	V	V	V	V																												V					
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V		V	V		V	V	V	V	V	V	V	V																										V					
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
F	2012	Camaro	Body	Passenger Presence Module																																V																								
F	2012	Camaro	Body	Instrument Cluster																																	V																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
F	2012	Camaro	Body	Head-Up Display Module																																																								
F	2012	Camaro	Body	Auxiliary Gage Module																																																								
F	2012	Camaro	Body	Headlamp Control Module																																																								
F	2012	Camaro	Body	Radio																																																								
F	2012	Camaro	Body	Multimedia Player Interface Module																																V																								
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																								
F	2012	Camaro	Body	Mobile Telephone Control Module																																V																								
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module																														V													V	V	V	V	V									
F	2012	Camaro	Body	Front Seat Heating Control Module																																						V	V																	
F	2012	Camaro	Body	Folding Top Control Module																																																								
F	2012	Camaro	Body	Parking Assist Control Module																																V																								
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																				
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump																																																								
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow																																																								
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																				V																																				
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump																																																								
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow																																																								
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																								
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																				V																																				
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump																																																								
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow																																																								
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																								
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																								
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump																																																								
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow																																																								
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																								
F	2013	Camaro	Chassis	Electronic Brake Control Module					V																																																			
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																								
F	2013	Camaro	Chassis	Power Steering Control Module																																																								
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
F	2013	Camaro	Chassis	Suspension Control Module																																																								
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V		V	V		V	V	V	V	V	V	V	V																									V								
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V		V	V		V	V	V	V	V	V	V	V																								V								
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
F	2013	Camaro	Body	Passenger Presence Module																																																								
F	2013	Camaro	Body	Instrument Cluster																																V																								
F	2013	Camaro	Body	Head-Up Display Module																																																								
F	2013	Camaro	Body	Auxiliary Gage Module																																																								
F	2013	Camaro	Body	Headlamp Control Module																																																								
F	2013	Camaro	Body	Radio																																																								
F	2013	Camaro	Body	Multimedia Player Interface Module																																V																								
F	2013	Camaro	Body	Mobile Telephone Control Module																																V																								
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
F	2013	Camaro	Body	HVAC Control Module																															V												V	V	V	V	V								
F	2013	Camaro	Body	Front Seat Heating Control Module																																					V	V																	
F	2013	Camaro	Body	Folding Top Control Module																																																							
F	2013	Camaro	Body	Parking Assist Control Module																																V																								
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																			
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																							
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																				V																																			
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																							
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																				V																																			
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																						
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																						
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																						
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																				V																																			
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																						
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																						
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																						
F	2014	Camaro	Powertrain	Transmission Control Module																																																						
F	2014	Camaro	Chassis	Electronic Brake Control Module					V																																																		
F	2014	Camaro	Chassis	Parking Brake Control Module																																																						
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																						
F	2014	Camaro	Chassis	Power Steering Control Module																																																						
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
F	2014	Camaro	Chassis	Suspension Control Module																																																						
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V		V	V		V	V	V	V	V	V	V	V																								V						
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V		V	V		V	V	V	V	V	V	V	V																								V						
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
F	2014	Camaro	Body	Passenger Presence Module																																V																							
F	2014	Camaro	Body	Instrument Cluster																																	V																						
F	2014	Camaro	Body	Head-Up Display Module																																																						
F	2014	Camaro	Body	Auxiliary Gage Module																																																						
F	2014	Camaro	Body	Headlamp Control Module																																																					
F	2014	Camaro	Body	Radio																																																					
F	2014	Camaro	Body	Mobile Telephone Control Module																																	V																					
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																	
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																	
F	2014	Camaro	Body	HVAC Control Module																															V												V	V	V	V	V								
F	2014	Camaro	Body	Front Seat Heating Control Module																																					V	V																	
F	2014	Camaro	Body	Folding Top Control Module																																																						
F	2014	Camaro	Body	Parking Assist Control Module																																V																							
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module																				V																																			
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																						
F	2014	SS	Powertrain	Chassis Control Module																																																						
F	2014	SS	Chassis	Electronic Brake Control Module					V																																																	
F	2014	SS	Chassis	Parking Brake Control Module																																																						
F	2014	SS	Chassis	Power Steering Control Module	V																																																					
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
F	2014	SS	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V	V	V	V	V																								V						
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
F	2014	SS	Body	Passenger Presence Module																																V																							
F	2014	SS	Body	Instrument Cluster																																	V																						
F	2014	SS	Body	Head-Up Display Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
F	2014	SS	Body	Radio Control																																	V																								
F	2014	SS	Body	HVAC Control																																																								
F	2014	SS	Body	Headlamp Control Module																																																								
F	2014	SS	Body	Trailer Interface Control Module																																																								
F	2014	SS	Body	Radio																																																								
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
F	2014	SS	Body	HVAC Control Module																														V														V	V	V		V							
F	2014	SS	Body	Seat Memory Control Module - Driver																																																								
F	2014	SS	Body	Keyless Entry Control Module																																																								
F	2014	SS	Body	Right Side Object Detection Control Module																																																								
F	2014	SS	Body	Left Side Object Detection Control Module																																																								
F	2014	SS	Body	Parking Assist Control Module																																	V																								
F	2014	SS	Body	Frontview Camera Module																																																								
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																				
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																				V																																				
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																				V																																				
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																								
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																				V																																				
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																								
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																								
F	2015	Camaro	Powertrain	Transmission Control Module																																																								
F	2015	Camaro	Chassis	Electronic Brake Control Module					V																																																			
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																								
F	2015	Camaro	Chassis	Power Steering Control Module																																																								
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
F	2015	Camaro	Chassis	Suspension Control Module																																																								
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V		V	V		V	V	V	V	V	V	V	V																													V				
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V		V	V		V	V	V	V	V	V	V	V																													V				
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
F	2015	Camaro	Body	Passenger Presence Module																																V																								
F	2015	Camaro	Body	Instrument Cluster																																	V																								
F	2015	Camaro	Body	Head-Up Display Module																																																								
F	2015	Camaro	Body	Auxiliary Gage Module																																																								
F	2015	Camaro	Body	Headlamp Control Module																																																								
F	2015	Camaro	Body	Radio																																																								
F	2015	Camaro	Body	Mobile Telephone Control Module																																	V																								
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6																																		V	V	V	V																				
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																		V	V	V																				
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
F	2015	Camaro	Body	HVAC Control Module																														V														V	V	V	V	V							
F	2015	Camaro	Body	Front Seat Heating Control Module																																						V	V																
F	2015	Camaro	Body	Folding Top Control Module																																																								
F	2015	Camaro	Body	Parking Assist Control Module																																	V																								
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																				V																																				
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																									
F	2015	SS	Powertrain	Fuel Injector Control Module																																																										
F	2015	SS	Powertrain	Chassis Control Module																																																										
F	2015	SS	Chassis	Electronic Brake Control Module					V																																																					
F	2015	SS	Chassis	Parking Brake Control Module																																																										
F	2015	SS	Chassis	Power Steering Control Module	V																																																									
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
F	2015	SS	Chassis	Suspension Control Module																																																										
F	2015	SS	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V	V	V	V	V																								V								
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
F	2015	SS	Body	Passenger Presence Module																																V																										
F	2015	SS	Body	Instrument Cluster																																	V																								
F	2015	SS	Body	Head-Up Display Module																																																									
F	2015	SS	Body	Radio Control																																	V																								
F	2015	SS	Body	HVAC Control																																																									
F	2015	SS	Body	Headlamp Control Module																																																									
F	2015	SS	Body	Trailer Interface Control Module																																																									
F	2015	SS	Body	Radio																																																									
F	2015	SS	Body	Telematics Communication Interface Control Module																																		V	V	V																					
F	2015	SS	Body	HVAC Control Module																															V													V	V	V		V								
F	2015	SS	Body	Seat Memory Control Module - Driver																																																									
F	2015	SS	Body	Keyless Entry Control Module																																																									
F	2015	SS	Body	Right Side Object Detection Control Module																																																									
F	2015	SS	Body	Left Side Object Detection Control Module																																																									
F	2015	SS	Body	Parking Assist Control Module																																	V																								
F	2015	SS	Body	Frontview Camera Module																																																									
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																				V																																					
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																				V																																					
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																				V																																					
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																				V																																					
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																				V																																					
F	2016	Camaro	Powertrain	Transmission Control Module																																																										
F	2016	Camaro	Chassis	Electronic Brake Control Module					V																																																					
F	2016	Camaro	Chassis	Parking Brake Control Module																																																										
F	2016	Camaro	Chassis	Power Steering Control Module																																																										
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
F	2016	Camaro	Chassis	Suspension Control Module																																																										
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V			V	V		V	V	V	V	V	V	V	V																								V								
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V			V	V		V	V	V	V	V	V	V	V																								V								
F	2016	Camaro	Body	Serial Data Gateway Module																																																										
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
F	2016	Camaro	Body	Passenger Presence Module																																V																										
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																	V																								
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																	V																								
F	2016	Camaro	Body	Head-Up Display Module																																																									
F	2016	Camaro	Body	Auxiliary Gage Module																																																									
F	2016	Camaro	Body	Radio Controls																																																									
F	2016	Camaro	Body	HVAC Controls																																																									
F	2016	Camaro	Body	Vehicle Performance Data Recorder																																																									
F	2016	Camaro	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
F	2016	Camaro	Body	Amplifier																																																								
F	2016	Camaro	Body	Media Disc Player																																																								
F	2016	Camaro	Body	Human Machine Interface Control Module																																																								
F	2016	Camaro	Body	Navigation Control Module																																																								
F	2016	Camaro	Body	Mobile Telephone Control Module																																V																								
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)																														V														V	V		V									
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)																														V														V	V		V									
F	2016	Camaro	Body	Seat Memory Control Module - Driver																																																								
F	2016	Camaro	Body	Folding Top Control Module																																																								
F	2016	Camaro	Body	Keyless Entry Control Module																																																								
F	2016	Camaro	Body	Right Side Object Detection Control Module																																																								
F	2016	Camaro	Body	Left Side Object Detection Control Module																																																								
F	2016	Camaro	Body	Parking Assist Control Module																																V																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																				V																																				
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2016	SS	Powertrain	Fuel Injector Control Module																																																								
F	2016	SS	Chassis	Electronic Brake Control Module					V																																																			
F	2016	SS	Chassis	Parking Brake Control Module																																																								
F	2016	SS	Chassis	Power Steering Control Module	V																																																							
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
F	2016	SS	Chassis	Suspension Control Module																																																								
F	2016	SS	Body	Body Control Module						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																											V					
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
F	2016	SS	Body	Passenger Presence Module																															V																									
F	2016	SS	Body	Instrument Cluster																																V																								
F	2016	SS	Body	Head-Up Display Module																																																								
F	2016	SS	Body	Radio Control																																V																								
F	2016	SS	Body	HVAC Control																																																								
F	2016	SS	Body	Trailer Interface Control Module																																																								
F	2016	SS	Body	Radio																																																								
F	2016	SS	Body	Telematics Communication Interface Control Module																																V	V	V																						
F	2016	SS	Body	HVAC Control Module																														V													V	V	V		V									
F	2016	SS	Body	Seat Memory Control Module - Driver																																																								
F	2016	SS	Body	Keyless Entry Control Module																																																								
F	2016	SS	Body	Right Side Object Detection Control Module																																																								
F	2016	SS	Body	Left Side Object Detection Control Module																																																								
F	2016	SS	Body	Parking Assist Control Module																																V																								
F	2016	SS	Body	Frontview Camera Module																																																								
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																				
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																				
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
G	2016	Malibu	Powertrain	Fuel Injector Control Module					V																																																			
G	2016	Malibu	Powertrain	Chassis Control Module																																																					V			
G	2016	Malibu	Chassis	Electronic Brake Control Module					V																																																			

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2016	Malibu	Chassis	Parking Brake Control Module																																																										
G	2016	Malibu	Chassis	Power Steering Control Module	V	V	V																																																							
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																									V							
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																									V							
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
G	2016	Malibu	Body	Passenger Presence Module																															V																											
G	2016	Malibu	Body	Instrument Cluster																																V																										
G	2016	Malibu	Body	Headlamp Control Module																																																										
G	2016	Malibu	Body	Radio																																																										
G	2016	Malibu	Body	Digital Radio Receiver Control Module																																																										
G	2016	Malibu	Body	Multimedia Player Interface Module																																V																										
G	2016	Malibu	Body	Mobile Telephone Control Module																																V																										
G	2016	Malibu	Body	Telematics Communication Interface Control Module																																	V	V	V																							
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																														V													V	V		V											
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																														V													V	V		V											
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																														V													V	V		V											
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																														V													V	V		V											
G	2016	Malibu	Body	Seat Memory Control Module																																																										
G	2016	Malibu	Body	Front Seat Heating Control Module																																					V	V																				
G	2016	Malibu	Body	Rear Seat Heating Control Module																																							V	V																		
G	2016	Malibu	Body	Keyless Entry Control Module																																																										
G	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
G	2016	Malibu	Body	Parking Assist Control Module																																V																										
G	2016	Malibu	Body	Frontview Camera Module																																																										
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
H	2010	Sail	Powertrain	Transmission Control Module																																																										
H	2010	Sail	Chassis	Electronic Brake Control Module																																																										
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																	
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
H	2011	Sail	Powertrain	Transmission Control Module																																																										
H	2011	Sail	Chassis	Electronic Brake Control Module																																																										
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																	
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	Transmission Control Module																																																										
H	2012	Sail	Chassis	Electronic Brake Control Module																																																										
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																	
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	Transmission Control Module																																																										
H	2013	Sail	Chassis	Electronic Brake Control Module																																																										
H	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	Transmission Control Module																																																										
H	2014	Sail	Chassis	Electronic Brake Control Module																																																										
H	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																
H	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																	V							
H	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																	V							
H	2015	Sail	Chassis	Electronic Brake Control Module																																																										
H	2015	Sail	Chassis	Power Steering Control Module	V		V																																																							
H	2015	Sail	Body	Body Control Module						V		V		V					V		V		V																																							
H	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
H	2015	Sail	Body	Radio/HVAC Control																																																										
H	2015	Sail	Body	HVAC Control Module																														V													V	V	V	V	V										
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																	V							
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																	V							
H	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																										
H	2016	Sail	Chassis	Electronic Brake Control Module																																																										
H	2016	Sail	Chassis	Power Steering Control Module	V		V																																																							
H	2016	Sail	Body	Body Control Module						V		V		V					V		V		V																																							
H	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
H	2016	Sail	Body	Radio/HVAC Control																																																										
H	2016	Sail	Body	Radio																																																										
H	2016	Sail	Body	HVAC Control Module																														V													V	V	V	V	V										
J	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
J	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
J	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
J	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
J	2004	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
J	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
J	2004	Optra	Body	Remote Function Actuation																														V																												
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel																																																										
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel Transmission Control Module																																																										
J	2004	Cavalier	Chassis	Anti-lock Brake System																																																										
J	2004	Cavalier	Body	Body Control Module																														V																												
J	2004	Cavalier	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2004	Cavalier	Body	Instrument Panel Cluster																																																										
J	2004	Cavalier	Body	Radio																																																										
J	2004	Cavalier	Body	Supplemental Inflatable Restraint																																																										
J	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
J	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
J	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
J	2005	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
J	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
J	2005	Optra	Body	Remote Function Actuation																															V																												
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
J	2005	Cavalier	Chassis	Anti-lock Brake System																																																										
J	2005	Cavalier	Body	Body Control Module																															V																												
J	2005	Cavalier	Body	Digital Radio Receiver																																																										
J	2005	Cavalier	Body	Instrument Panel Cluster																																																										
J	2005	Cavalier	Body	Radio																																																										
J	2005	Cavalier	Body	Supplemental Inflatable Restraint																																																										
J	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
J	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
J	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
J	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
J	2006	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
J	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2006	ALL	Body	Remote Function Actuation																															V																												
J	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
J	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
J	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
J	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
J	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																										
J	2007	ALL	Powertrain	4 Speed Automatic																																																										
J	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																										
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																										
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																										
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																										
J	2007	ALL	Chassis	Tire Pressure Monitor																																																										
J	2007	ALL	Body	Remote Function Actuation																															V																												
J	2007	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
J	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
J	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
J	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																										
J	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
J	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																																																										
J	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																										
J	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2008	ALL	Chassis	Tire Pressure Monitor																																																										
J	2008	ALL	Body	Remote Function Actuation																														V																												
J	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
J	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
J	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
J	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																										
J	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
J	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																										
J	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2009	ALL	Chassis	Tire Pressure Monitor																																																										
J	2009	ALL	Body	Remote Function Actuation																														V																												
J	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																										
J	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																										
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																										
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																										
J	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																										
J	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																										
J	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																										
J	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																										
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																										
J	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																										
J	2010	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
J	2010	Cruze	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V																																		
J	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V	V																											
J	2010	Cruze	Body	Passenger Presence Module																															V																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2010	Cruze	Body	Instrument Cluster																																V																								
J	2010	Cruze	Body	Trailer Interface Control Module																																V																								
J	2010	Cruze	Body	Radio																																																								
J	2010	Cruze	Body	Multimedia Player Interface Module																																V																								
J	2010	Cruze	Body	Mobile Telephone Control Module																																V																								
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																			
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
J	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																														V											V	V	V	V	V									
J	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																														V											V	V	V	V	V									
J	2010	Cruze	Body	Keyless Entry Control Module																																																							
J	2010	Cruze	Body	Parking Assist Control Module																																V																								
J	2010	Cruze	Body	Steering Column Lock Control Module																																																							
J	2010	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																							
J	2010	Other	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																							
J	2010	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																						
J	2010	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																						
J	2010	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																						
J	2010	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																						
J	2010	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																						
J	2010	Other	Powertrain	Transmission Control Module 5 Speed																																																						
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																						
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control No																																																						
J	2010	Other	Chassis	Tire Pressure Monitor																																																						
J	2010	Other	Body	Remote Function Actuation																														V																								
J	2010	Other	Body	Supplemental Inflatable Restraint																																																						
J	2010	Other	Body	Supplemental Inflatable Restraint																																																						
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																			V
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																						V
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																						
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																						
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																						
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																						
J	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																						
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																						
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																						
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																						
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																						
J	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																						
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																						
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																						
J	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																						
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																						
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																						
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																						
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																						
J	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																						
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																			
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																						
J	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																						
J	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																						
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																								
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																									
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
J	2011	Cruze	Chassis	Electronic Brake Control Module																																																									
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
J	2011	Cruze	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																										V							
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2011	Cruze	Body	Passenger Presence Module																																V																									
J	2011	Cruze	Body	Instrument Cluster																																	V																							
J	2011	Cruze	Body	Trailer Interface Control Module																																	V																							
J	2011	Cruze	Body	Radio																																																								
J	2011	Cruze	Body	Multimedia Player Interface Module																																	V																							
J	2011	Cruze	Body	Mobile Telephone Control Module																																	V																							
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																			
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																														V												V	V	V	V	V									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																														V												V	V	V	V	V									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																														V												V	V	V	V	V									
J	2011	Cruze	Body	Keyless Entry Control Module																																																								
J	2011	Cruze	Body	Parking Assist Control Module																																	V																							
J	2011	Cruze	Body	Steering Column Lock Control Module																																																								
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																								
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2011	Other	Powertrain	Transmission Control Module 5 Speed																																																								
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No																																																								
J	2011	Other	Chassis	Tire Pressure Monitor																																																								
J	2011	Other	Body	Remote Function Actuation																														V																										
J	2011	Other	Body	Supplemental Inflatable Restraint																																																								
J	2011	Other	Body	Supplemental Inflatable Restraint																																																								
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																								
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																								
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																								
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																								
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																					
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																				V																																					
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																									
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																					
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
J	2012	Aveo	Powertrain	Fuel Pump Control Module																																																									
J	2012	Aveo	Powertrain	Fuel Injector Control Module																																																									
J	2012	Aveo	Chassis	Electronic Brake Control Module																																																									
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2012	Aveo	Chassis	Electric Power Steering Control Module																																																									
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
J	2012	Aveo	Body	Body Control Module Hatchback						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V							
J	2012	Aveo	Body	Body Control Module Sedan						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V							
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2012	Aveo	Body	Passenger Presence Module																																V																									
J	2012	Aveo	Body	Instrument Cluster																																	V																							
J	2012	Aveo	Body	Radio																																																									
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																									
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																												V													
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V													
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																												V													
J	2012	Aveo	Body	Front Seat Heating Control Module																																						V	V																			
J	2012	Aveo	Body	Parking Assist Control Module																																																									
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																									
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																									
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																									
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																									
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
J	2012	Cobalt	Chassis	Electronic Brake Control Module																																																									
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																									
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
J	2012	Cobalt	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V																																					
J	2012	Cobalt	Body	Passenger Presence Module																																V																									
J	2012	Cobalt	Body	Instrument Cluster																																	V																							
J	2012	Cobalt	Body	Radio																																																								
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																									
J	2012	Cobalt	Body	Telematics Communication Interface Control Module																																	V	V	V	V																			
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																										V													

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V											
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																												V											
J	2012	Cobalt	Body	Front Seat Heating Control Module																																					V	V																		
J	2012	Cobalt	Body	Parking Assist Control Module																																V																							
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																			
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																							
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																						
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																						
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																						
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																						
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																						
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																						
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																						
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																						
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																						
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																						
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																						
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																						
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																						
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																						
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																						
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																						
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																						
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																						
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																						
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																						
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																						
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																						
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																						
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																			
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																						
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																						
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																						
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																						
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																						
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																						
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																						
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																						
J	2012	Cruze	Chassis	Electronic Brake Control Module																																																						
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																						
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
J	2012	Cruze	Body	Body Control Module Hatchback						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V						
J	2012	Cruze	Body	Body Control Module Sedan						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V						
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																				V	V	V	V	V	V	V																												
J	2012	Cruze	Body	Passenger Presence Module																																V																							
J	2012	Cruze	Body	Instrument Cluster																																	V																						
J	2012	Cruze	Body	Trailer Interface Control Module																																	V																						
J	2012	Cruze	Body	Radio																																																						
J	2012	Cruze	Body	Multimedia Player Interface Module																																	V																						
J	2012	Cruze	Body	Mobile Telephone Control Module																																	V																						
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																														V										V	V	V	V	V										
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																														V										V	V	V	V	V										
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																														V										V	V	V	V	V										
J	2012	Cruze	Body	Keyless Entry Control Module																																																						
J	2012	Cruze	Body	Parking Assist Control Module																																V																						
J	2012	Cruze	Body	Steering Column Lock Control Module																																																					
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																					
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																					
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																					
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																					
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																					
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																					
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																					
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																					
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																					
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																					
J	2012	Sonic (First Gen)	Body	Remote Function Actuation																														V																								
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																					
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																		
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																		
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																					
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																		
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																					
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																					
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																		
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																				V																																		
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																					
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module																																																					
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																		
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																					
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																					
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																					
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																					
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																					
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module Chassis Expansion CAN BUS				V	V																																																			
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module High Speed CAN Bus				V	V																																																		
J	2012	Sonic (Second Gen)	Body	Body Control Module Hatchback						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V						
J	2012	Sonic (Second Gen)	Body	Body Control Module Sedan						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V						
J	2012	Sonic (Second Gen)	Body	Passenger Presence Module																															V																									
J	2012	Sonic (Second Gen)	Body	Instrument Cluster																																V																								
J	2012	Sonic (Second Gen)	Body	Radio																																																							
J	2012	Sonic (Second Gen)	Body	Telematic Vehicle Localization and Immobilization Control Module																																																							
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																			
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																											V										
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V										
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																											V										
J	2012	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																					V	V																	
J	2012	Sonic (Second Gen)	Body	Parking Assist Control Module																																																						
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																			
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																						
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																				V																																			
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																						
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																						
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																						
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																						
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																						
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																			
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																						
J	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																						
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																			
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																						
J	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																						
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																				V																																			
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																						
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																						
J	2013	Aveo	Powertrain	Fuel Pump Control Module																																																						
J	2013	Aveo	Powertrain	Fuel Injector Control Module																																																						
J	2013	Aveo	Chassis	Electronic Brake Control Module																																																						
J	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																						
J	2013	Aveo	Chassis	Electric Power Steering Control Module																																																						
J	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
J	2013	Aveo	Body	Body Control Module Hatchback						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V						
J	2013	Aveo	Body	Body Control Module Sedan						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V						
J	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
J	2013	Aveo	Body	Passenger Presence Module																															V																							
J	2013	Aveo	Body	Instrument Cluster																																V																						
J	2013	Aveo	Body	Radio																																																					
J	2013	Aveo	Body	Telematics Communication Interface Control Module																																	V	V	V	V																	
J	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																											V										
J	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V										
J	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																											V										
J	2013	Aveo	Body	Front Seat Heating Control Module																																					V	V																	
J	2013	Aveo	Body	Parking Assist Control Module																																																					
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																				V																																			
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																								
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																								
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																								
J	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																								
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																				V																																			
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
J	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																								
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																				V																																			
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																								
J	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																								
J	2013	Cobalt	Chassis	Electronic Brake Control Module																																																								
J	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module			V	V																																																				
J	2013	Cobalt	Body	Body Control Module						V	V	V	V	V	V		V	V		V		V	V																																				
J	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V	V																									
J	2013	Cobalt	Body	Instrument Cluster																																V																								
J	2013	Cobalt	Body	Radio																																																								
J	2013	Cobalt	Body	Telematics Communication Interface Control Module																																V	V	V	V																				
J	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																										V														
J	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																										V														
J	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																										V														
J	2013	Cobalt	Body	Front Seat Heating Control Module																																				V	V																		
J	2013	Cobalt	Body	Parking Assist Control Module																															V																									
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																			
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																			
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																			V				
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																								
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																			V	V			
J	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																								
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																								
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																								
J	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																				
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																						V		
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																								
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																					V	V		
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																				V																														V						
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																						V		
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																					V	V		
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
J	2013	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
J	2013	Cruze	Body	Body Control Module Hatchback						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																														V		
J	2013	Cruze	Body	Body Control Module Sedan						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																														V		
J	2013	Cruze	Body	Body Control Module Station Wagon						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																														V		
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2013	Cruze	Body	Passenger Presence Module																																V																								
J	2013	Cruze	Body	Instrument Cluster																																	V																							
J	2013	Cruze	Body	Trailer Interface Control Module																																	V																							
J	2013	Cruze	Body	Radio																																																								
J	2013	Cruze	Body	Digital Radio Receiver Control Module																																																								
J	2013	Cruze	Body	Multimedia Player Interface Module																																	V																							
J	2013	Cruze	Body	Mobile Telephone Control Module																																	V																							
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																															V												V	V	V	V	V									
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																															V												V	V	V	V										
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																															V												V	V	V	V	V									
J	2013	Cruze	Body	Front Seat Heating Control Module																																					V	V																		
J	2013	Cruze	Body	Keyless Entry Control Module																																																								
J	2013	Cruze	Body	Right Side Object Detection Control Module																																																								
J	2013	Cruze	Body	Left Side Object Detection Control Module																																																								
J	2013	Cruze	Body	Parking Assist Control Module																																V																								
J	2013	Cruze	Body	Steering Column Lock Control Module																																																								
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																								
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																									
J	2013	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																									
J	2013	Sonic (First Gen)	Body	Remote Function Actuation																														V																											
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																								
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																				
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																				V																																				
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																				
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																				
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																				
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																				V																																				
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																				
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																				V																																				
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																								
J	2013	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
J	2013	Sonic (Second Gen)	Body	Body Control Module Hatchback						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																							V							
J	2013	Sonic (Second Gen)	Body	Body Control Module Sedan						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																							V							
J	2013	Sonic (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
J	2013	Sonic (Second Gen)	Body	Passenger Presence Module																																V																							
J	2013	Sonic (Second Gen)	Body	Instrument Cluster																																	V																						
J	2013	Sonic (Second Gen)	Body	Radio																																																								
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																										V												
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																										V												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																												V													
J	2013	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																					V	V																		
J	2013	Sonic (Second Gen)	Body	Parking Assist Control Module																																																								
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																				V																																				
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
J	2013	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																								
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																				V																																				
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																								
J	2013	Spin	Powertrain	1.8L LMD Transmission Control Module																																																								
J	2013	Spin	Chassis	Electronic Brake Control Module																																																								
J	2013	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Spin	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
J	2013	Spin	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V																																					
J	2013	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2013	Spin	Body	Instrument Cluster																																V																								
J	2013	Spin	Body	Radio																																																								
J	2013	Spin	Body	HVAC Control Module Heater Only (C41)																																												V												
J	2013	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V												
J	2013	Spin	Body	HVAC Control Module Single Zone (C60)																																												V												
J	2013	Spin	Body	Parking Assist Control Module																																V																								
J	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																								
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																				
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																				V																																				
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																								
J	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																								
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																								
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																								
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																				V																																				
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																								
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																				
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																				
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																					
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																				V																																					
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																				V																																					
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	Chassis Control Module																																																										
J	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Aveo	Chassis	Power Steering Control Module																																																										
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
J	2014	Aveo	Body	Body Control Module Hatchback						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																								V							
J	2014	Aveo	Body	Body Control Module Sedan						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																								V							
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																															
J	2014	Aveo	Body	Instrument Cluster																																V																								
J	2014	Aveo	Body	Radio																																																									
J	2014	Aveo	Body	Telematics Communication Interface Control Module																																	V	V	V	V																				
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																											V											
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V											
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																											V											
J	2014	Aveo	Body	Front Seat Heating Control Module																																					V	V																		
J	2014	Aveo	Body	Keyless Entry Control Module																																																									
J	2014	Aveo	Body	Parking Assist Control Module																																																									
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																									
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																				V																																					
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																									
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																									
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																									
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																									
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																				V																																					
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																				V																																					
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																									
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																									
J	2014	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
J	2014	Cobalt	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V																																					
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2014	Cobalt	Body	Instrument Cluster																																V																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2014	Cobalt	Body	Radio																																																								
J	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																											V											
J	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V											
J	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																											V											
J	2014	Cobalt	Body	Front Seat Heating Control Module																																					V	V																	
J	2014	Cobalt	Body	Parking Assist Control Module																																V																							
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																			
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																							
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																			
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																						
J	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																						
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																			
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																						
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																				V		
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																						
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																			V	V		
J	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																						
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																						
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																						
J	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																						
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																						
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																						
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																						
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																						
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																			V		
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																						
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																			V	V		
J	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																						
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																				V																																			
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																						
J	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																						
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																						
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																						
J	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																						
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																						
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																						
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																						
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																						
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																						
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																						
J	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																						
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																						
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																						
J	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																						
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																			
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																						
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																				V		
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																						
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																			V	V		
J	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																						
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																				V																												V							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																														V							
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																			V		
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																					
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																	V	V		
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																				
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																				
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																				
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																				
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																				
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																			V		
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																				
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																	V	V		
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																				
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																	V			
J	2014	Cruze	Powertrain	Fuel Injector Control Module																																																				
J	2014	Cruze	Chassis	Electronic Brake Control Module																																																				
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																				
J	2014	Cruze	Chassis	Power Steering Control Module	V	V	V																																																		
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																
J	2014	Cruze	Body	Body Control Module Hatchback						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V					
J	2014	Cruze	Body	Body Control Module Sedan						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V					
J	2014	Cruze	Body	Body Control Module Station Wagon						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V					
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																					
J	2014	Cruze	Body	Passenger Presence Module																																V																				
J	2014	Cruze	Body	Instrument Cluster																																	V																			
J	2014	Cruze	Body	Trailer Interface Control Module																																	V																			
J	2014	Cruze	Body	Radio																																																				
J	2014	Cruze	Body	Digital Radio Receiver Control Module																																																				
J	2014	Cruze	Body	Multimedia Player Interface Module																																	V																			
J	2014	Cruze	Body	Mobile Telephone Control Module																																	V																			
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V															
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V						
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																														V												V	V	V	V							
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V						
J	2014	Cruze	Body	Front Seat Heating Control Module																																					V	V														
J	2014	Cruze	Body	Keyless Entry Control Module																																																				
J	2014	Cruze	Body	Right Side Object Detection Control Module																																																				
J	2014	Cruze	Body	Left Side Object Detection Control Module																																																				
J	2014	Cruze	Body	Parking Assist Control Module																																	V																			
J	2014	Cruze	Body	Steering Column Lock Control Module																																																				
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																				
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module																																																				
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																				
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																				
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																				
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																				
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																				V																																
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																				
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																						
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2014	Sonic	Powertrain	1.4L LDD Chassis Control Module																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																						
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Chassis Control Module																																																										
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																				V																																						
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																				V																																						
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																						
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																				V																																						
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Chassis Control Module																																																										
J	2014	Sonic	Powertrain	Fuel Injector Control Module																																																										
J	2014	Sonic	Chassis	Electronic Brake Control Module																																																										
J	2014	Sonic	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Sonic	Chassis	Power Steering Control Module																																																										
J	2014	Sonic	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
J	2014	Sonic	Body	Body Control Module Hatchback						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V							
J	2014	Sonic	Body	Body Control Module Sedan						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V							
J	2014	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2014	Sonic	Body	Passenger Presence Module																																V																									
J	2014	Sonic	Body	Instrument Cluster																																	V																							
J	2014	Sonic	Body	Radio																																																									
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																			
J	2014	Sonic	Body	HVAC Control Module Heater Only (C41)																																											V												
J	2014	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V												
J	2014	Sonic	Body	HVAC Control Module Single Zone (C60)																																											V												
J	2014	Sonic	Body	Front Seat Heating Control Module																																						V	V																	
J	2014	Sonic	Body	Parking Assist Control Module																																																									
J	2014	Sonic	Body	Frontview Camera Module																																																									
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.5L L2B Transmission Control Module																																																								
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Automatic Transmission																				V																																				
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																				V																																				
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																								
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																				V																																				
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.8L LMD Transmission Control Module																																																								
J	2014	Spin	Chassis	Electronic Brake Control Module																																																								
J	2014	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2014	Spin	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
J	2014	Spin	Body	Body Control Module						V	V	V	V	V	V	V	V		V			V	V																																					
J	2014	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2014	Spin	Body	Instrument Cluster																																	V																							
J	2014	Spin	Body	Radio																																																								
J	2014	Spin	Body	HVAC Control Module Heater Only (C41)																																												V												
J	2014	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V												
J	2014	Spin	Body	HVAC Control Module Single Zone (C60)																																												V												
J	2014	Spin	Body	Parking Assist Control Module																																V																								
J	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																								
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																				
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																				V																																				
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																								
J	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																				V																																				
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																				
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																				
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																								
J	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																									
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																					
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																				V																																					
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																									
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																									
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																				V																																					
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
J	2015	Aveo	Powertrain	Chassis Control Module																																																									
J	2015	Aveo	Powertrain	Fuel Injector Control Module																																																									
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																									
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																									
J	2015	Aveo	Chassis	Power Steering Control Module																																																									
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
J	2015	Aveo	Body	Body Control Module Hatchback						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V							
J	2015	Aveo	Body	Body Control Module Sedan						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V							
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																															
J	2015	Aveo	Body	Instrument Cluster																																V																							
J	2015	Aveo	Body	Radio																																																								
J	2015	Aveo	Body	Telematics Communication Interface Control Module																																	V	V	V																			
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																											V											
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V											
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																											V											
J	2015	Aveo	Body	Front Seat Heating Control Module																																					V	V																	
J	2015	Aveo	Body	Keyless Entry Control Module																																																								
J	2015	Aveo	Body	Parking Assist Control Module																																																								
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																				V																																				
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																								
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																								
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																				V																																				
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																								
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																				V																																				
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																								
J	2015	Cobalt	Chassis	Electronic Brake Control Module																																																								
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
J	2015	Cobalt	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																																				
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2015	Cobalt	Body	Instrument Cluster																																V																							
J	2015	Cobalt	Body	Radio																																																							
J	2015	Cobalt	Body	Telematics Communication Interface Control Module																																	V	V	V																			
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																											V											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V											
J	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																												V											
J	2015	Cobalt	Body	Front Seat Heating Control Module																																					V	V																		
J	2015	Cobalt	Body	Parking Assist Control Module																																V																							
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																			
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																							
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																			
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																						
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																			V		
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																						
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																		V	V		
J	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																						
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																			
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																						
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																			V		
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																						
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																		V	V		
J	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																						
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																						
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																						
J	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																						
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																						
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																						
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																						
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																						
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																			V		
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																						
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																		V	V		
J	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																						
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																				V																																			
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																						
J	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																						
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																						
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																						
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																						
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																						
J	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																						
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																						
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																						
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																						
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																						
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																						
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																						
J	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																						
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																						
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																						
J	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																						
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																			
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																						
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																			V		
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																				V																											V									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																															V									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																				V				
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																				V	V			
J	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																				V				
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																				V	V			
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																			V	V				
J	2015	Cruze	Powertrain	Fuel Injector Control Module																																																								
J	2015	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2015	Cruze	Chassis	Power Steering Control Module	V	V	V																																																					
J	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
J	2015	Cruze	Body	Body Control Module Hatchback						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																										V						
J	2015	Cruze	Body	Body Control Module Sedan						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																										V						
J	2015	Cruze	Body	Body Control Module Station Wagon						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																										V						
J	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
J	2015	Cruze	Body	Passenger Presence Module																															V																									
J	2015	Cruze	Body	Instrument Cluster																																V																								
J	2015	Cruze	Body	Trailer Interface Control Module																																V																								
J	2015	Cruze	Body	Radio																																																								
J	2015	Cruze	Body	Digital Radio Receiver Control Module																																																								
J	2015	Cruze	Body	Multimedia Player Interface Module																																V																								
J	2015	Cruze	Body	Mobile Telephone Control Module																																V																								
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
J	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																														V													V	V	V	V	V									
J	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																														V													V	V	V	V										
J	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																														V													V	V	V	V	V									
J	2015	Cruze	Body	Front Seat Heating Control Module																																				V	V																			
J	2015	Cruze	Body	Keyless Entry Control Module																																																								
J	2015	Cruze	Body	Right Side Object Detection Control Module																																																								
J	2015	Cruze	Body	Left Side Object Detection Control Module																																																								
J	2015	Cruze	Body	Parking Assist Control Module																																V																								
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																				
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																				V																																				
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2015	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																											
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																							
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																							
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																							
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																							
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																				V																																							
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	1.6L LED Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																				V																																							
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																							
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																				V																																							
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2015	Sonic	Powertrain	Chassis Control Module																																																											
J	2015	Sonic	Powertrain	Fuel Injector Control Module																																																											
J	2015	Sonic	Chassis	Electronic Brake Control Module																																																											
J	2015	Sonic	Chassis	Power Steering Control Module																																																											
J	2015	Sonic	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
J	2015	Sonic	Body	Body Control Module Hatchback						V	V	V		V	V			V	V		V	V	V	V	V		V	V																								V								
J	2015	Sonic	Body	Body Control Module Sedan						V	V	V		V	V			V	V		V	V	V	V	V		V	V																								V								
J	2015	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2015	Sonic	Body	Passenger Presence Module																																V																									
J	2015	Sonic	Body	Instrument Cluster																																	V																							
J	2015	Sonic	Body	Radio																																																									
J	2015	Sonic	Body	Telematics Communication Interface Control Module																																		V	V	V																			
J	2015	Sonic	Body	HVAC Control Module Heater Only (C41)																																											V											
J	2015	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V											
J	2015	Sonic	Body	HVAC Control Module Single Zone (C60)																																											V											
J	2015	Sonic	Body	Front Seat Heating Control Module																																					V	V																	
J	2015	Sonic	Body	Parking Assist Control Module																																																										
J	2015	Sonic	Body	Frontview Camera Module																																																										
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.5L L2B Transmission Control Module																																																										
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																				V																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
J	2015	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																				V																																						
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2015	Spin	Chassis	Electronic Brake Control Module																																																										
J	2015	Spin	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
J	2015	Spin	Body	Body Control Module						V	V	V		V	V		V	V	V		V		V	V																																						
J	2015	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
J	2015	Spin	Body	Instrument Cluster																																V																										
J	2015	Spin	Body	Radio																																																									
J	2015	Spin	Body	Telematics Communication Interface Control Module																																	V	V	V																						
J	2015	Spin	Body	HVAC Control Module Heater Only (C41)																																												V											
J	2015	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V											
J	2015	Spin	Body	HVAC Control Module Single Zone (C60)																																												V											
J	2015	Spin	Body	Front Seat Heating Control Module																																					V	V																		
J	2015	Spin	Body	Parking Assist Control Module																																V																								
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																						
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																				V																																						
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
J	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																						
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
J	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																						
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																				V																																						
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																				V																																						
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
J	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2016	Aveo	Powertrain	Chassis Control Module																																																										
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2016	Aveo	Chassis	Power Steering Control Module																																																										
J	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
J	2016	Aveo	Body	Body Control Module Hatchback						V	V	V		V	V			V	V		V	V	V	V	V		V	V																																		
J	2016	Aveo	Body	Body Control Module Sedan						V	V	V		V	V			V	V		V	V	V	V	V		V	V																																		
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																										V																																
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																										
J	2016	Aveo	Body	Instrument Cluster																																V																										
J	2016	Aveo	Body	Radio																																																										
J	2016	Aveo	Body	Telematics Communication Interface Control Module																																	V	V	V																							
J	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V															
J	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																											V															
J	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																											V															
J	2016	Aveo	Body	Front Seat Heating Control Module																																					V	V																				
J	2016	Aveo	Body	Parking Assist Control Module																																V																										
J	2016	Aveo	Body	Keyless Entry Control Module																																																										
J	2016	Aveo	Body	Frontview Camera Module																																																										
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																				V																																						
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																				V																																						
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																				V																																						
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2016	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
J	2016	Cobalt	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V				V																																		
J	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Cobalt	Body	Instrument Cluster																																V																										
J	2016	Cobalt	Body	Radio Other																																																										
J	2016	Cobalt	Body	Radio (IOB)																																																										
J	2016	Cobalt	Body	Radio (UF7)																																																										
J	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																											V															
J	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V															
J	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																											V															
J	2016	Cobalt	Body	Front Seat Heating Control Module																																					V	V																				
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																								
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																								
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																								
J	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																								
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																				
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																				V																													V						
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																		V						
J	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
J	2016	Cruze	Powertrain	Fuel Injector Control Module																																																								
J	2016	Cruze	Powertrain	Chassis Control Module																																																				V	V			
J	2016	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2016	Cruze	Chassis	Power Steering Control Module																																																								
J	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module			V	V																																																				
J	2016	Cruze	Body	Body Control Module Hatchback					V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																													V					
J	2016	Cruze	Body	Body Control Module Sedan					V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																													V					
J	2016	Cruze	Body	Body Control Module Station Wagon					V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																													V					
J	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
J	2016	Cruze	Body	Passenger Presence Module																															V																									
J	2016	Cruze	Body	Instrument Cluster																																V																								
J	2016	Cruze	Body	Trailer Interface Control Module																															V																									
J	2016	Cruze	Body	Radio Other																																																								
J	2016	Cruze	Body	Radio (UF7)																																																								
J	2016	Cruze	Body	Multimedia Player Interface Module																															V																									
J	2016	Cruze	Body	Mobile Telephone Control Module																															V																									
J	2016	Cruze	Body	Telematics Communication Interface Control Module																																V	V	V																					
J	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																													V														V	V	V	V									
J	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																													V														V	V	V	V									
J	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																													V														V	V	V										
J	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																													V														V	V	V	V									
J	2016	Cruze	Body	Front Seat Heating Control Module																																				V	V																		
J	2016	Cruze	Body	Keyless Entry Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2016	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2016	Cruze	Body	Left Side Object Detection Control Module																																																											
J	2016	Cruze	Body	Parking Assist Control Module																																V																											
J	2016	Cruze	Body	Steering Column Lock Control Module																																																										
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																						
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																				V																																						
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																						
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																						
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																				V																																						
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module																																																										
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																						
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																				V																																						
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2016	Sonic	Powertrain	Chassis Control Module																																																										
J	2016	Sonic	Powertrain	Fuel Injector Control Module																																																										
J	2016	Sonic	Chassis	Electronic Brake Control Module																																																										
J	2016	Sonic	Chassis	Power Steering Control Module																																																										
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
J	2016	Sonic	Body	Body Control Module Hatchback						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V							
J	2016	Sonic	Body	Body Control Module Sedan						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V							
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
J	2016	Sonic	Body	Passenger Presence Module																																V																								
J	2016	Sonic	Body	Instrument Cluster																																	V																						
J	2016	Sonic	Body	Radio Other																																																								
J	2016	Sonic	Body	Radio (UF7)																																																								
J	2016	Sonic	Body	Radio (UH7)																																																								
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																										V													
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)																																										V													

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)																																												V											
J	2016	Sonic	Body	Front Seat Heating Control Module																																					V	V																	
J	2016	Sonic	Body	Parking Assist Control Module																																V																						
J	2016	Sonic	Body	Frontview Camera Module																																																					
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																					
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																					
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																					
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																					
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																					
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																					
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module																																																					
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																				V																																		
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																					
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																					
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																				V																																		
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																					
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module																																																					
J	2016	Spin	Chassis	Electronic Brake Control Module																																																					
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
J	2016	Spin	Body	Body Control Module						V	V	V		V	V		V	V	V		V		V	V																																		
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V	V																								
J	2016	Spin	Body	Instrument Cluster																																V																						
J	2016	Spin	Body	Radio																																																					
J	2016	Spin	Body	Telematics Communication Interface Control Module																																	V	V	V																			
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V										
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)																																											V										
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)																																											V										
J	2016	Spin	Body	Front Seat Heating Control Module																																					V	V																
J	2016	Spin	Body	Parking Assist Control Module																																V																						
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																					
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																					
K	2006	ALL	Powertrain	Transmission Control Module																																																					
K	2006	ALL	Chassis	Electronic Brake Control Module																																																					
K	2006	ALL	Body	Remote Function Actuation																														V																							
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																					
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																					
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																					
K	2007	ALL	Powertrain	Transmission Control Module																																																					
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module																																																					
K	2007	ALL	Chassis	Teves Electronic Brake Control Module																																																					
K	2007	ALL	Body	Remote Function Actuation																														V																							
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																					
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																					
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																					
K	2008	ALL	Powertrain	Transmission Control Module																																																					
K	2008	ALL	Chassis	Electronic Brake Control Module																																																					
K	2008	ALL	Body	Remote Function Actuation																														V																							
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																					
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																					
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																					
K	2009	ALL	Powertrain	Transmission Control Module																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2009	ALL	Chassis	Electronic Brake Control Module																																																								
K	2009	ALL	Body	Remote Function Actuation																															V																										
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2010	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																								
K	2010	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																								
K	2010	ALL	Powertrain	Transmission Control Module																																																								
K	2010	ALL	Chassis	Electronic Brake Control Module																																																								
K	2010	ALL	Body	Remote Function Actuation																															V																										
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2011	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																								
K	2011	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																								
K	2011	ALL	Powertrain	Transmission Control Module																																																								
K	2011	ALL	Chassis	Electronic Brake Control Module																																																								
K	2011	ALL	Body	Remote Function Actuation																															V																										
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2012	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																								
K	2012	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																								
K	2012	ALL	Powertrain	Transmission Control Module																																																								
K	2012	ALL	Chassis	Electronic Brake Control Module																																																								
K	2012	ALL	Body	Remote Function Actuation																															V																										
K	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2013	Onix	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																								
K	2013	Onix	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																								
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																								
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																								
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																								
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																								
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2013	Onix	Powertrain	Transmission Control Module																																																								
K	2013	Onix	Powertrain	Transmission Control Module																																																								
K	2013	Onix	Chassis	Electronic Brake Control Module																																																								
K	2013	Onix	Chassis	Electronic Brake Control Module																																																								
K	2013	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2013	Onix	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
K	2013	Onix	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V	V	V																																
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2013	Onix	Body	Instrument Cluster																																V																								
K	2013	Onix	Body	Radio																																																								
K	2013	Onix	Body	Parking Assist Control Module																																V																								
K	2013	Onix	Body	Remote Function Actuation																															V																										
K	2013	Prisma	Powertrain	Engine Control Module																				V																																				
K	2013	Prisma	Powertrain	Transmission Control Module																																																								
K	2013	Prisma	Chassis	Electronic Brake Control Module																																																								
K	2013	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2013	Prisma	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
K	2013	Prisma	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V	V	V																																
K	2013	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
K	2013	Prisma	Body	Instrument Cluster																																V																								
K	2013	Prisma	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2013	Prisma	Body	Parking Assist Control Module																																	V																							
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																							
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																						
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																						
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																					
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																					
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																					
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																					
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module																																																					
K	2014	Onix	Chassis	Electronic Brake Control Module																																																					
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																					
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
K	2014	Onix	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V	V	V																															
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
K	2014	Onix	Body	Instrument Cluster																																	V																						
K	2014	Onix	Body	Radio																																																						
K	2014	Onix	Body	Parking Assist Control Module																																	V																						
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																						
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																					
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module																																																					
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																					
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																					
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																					
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																					
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																					
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																					
K	2014	Prisma	Chassis	Electronic Brake Control Module																																																					
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																					
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module				V	V																																																
K	2014	Prisma	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V	V	V																														
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
K	2014	Prisma	Body	Instrument Cluster																																	V																						
K	2014	Prisma	Body	Radio																																																					
K	2014	Prisma	Body	Parking Assist Control Module																																	V																						
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																					
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																					
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																					
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																					
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																					
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																					
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																					
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module																																																					
K	2015	Onix	Chassis	Electronic Brake Control Module																																																					
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module				V	V																																																
K	2015	Onix	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V	V	V	V																														
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
K	2015	Onix	Body	Instrument Cluster																																	V																						
K	2015	Onix	Body	Radio																																																					
K	2015	Onix	Body	Parking Assist Control Module																																	V																						
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																					
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2015	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																									
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2015	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																									
K	2015	Prisma	Chassis	Electronic Brake Control Module																																																									
K	2015	Prisma	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
K	2015	Prisma	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V	V	V	V																																	
K	2015	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
K	2015	Prisma	Body	Instrument Cluster																																V																								
K	2015	Prisma	Body	Radio																																																								
K	2015	Prisma	Body	Parking Assist Control Module																																V																								
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2016	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																									
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2016	Onix	Powertrain	1.4L LKK Transmission Control Module																																																									
K	2016	Onix	Chassis	Electronic Brake Control Module																																																									
K	2016	Onix	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
K	2016	Onix	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V	V	V	V																																	
K	2016	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
K	2016	Onix	Body	Instrument Cluster																																V																								
K	2016	Onix	Body	Radio																																																								
K	2016	Onix	Body	Parking Assist Control Module																																V																								
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2016	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																									
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2016	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																									
K	2016	Prisma	Chassis	Electronic Brake Control Module																																																									
K	2016	Prisma	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
K	2016	Prisma	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V	V	V	V																																	
K	2016	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
K	2016	Prisma	Body	Instrument Cluster																																V																								
K	2016	Prisma	Body	Radio																																																								
K	2016	Prisma	Body	HVAC Control Module																																												V												
K	2016	Prisma	Body	Front Seat Heating Control Module																																					V	V																		
K	2016	Prisma	Body	Parking Assist Control Module																																V																								
L	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
L	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
L	2004	ALL	Powertrain	Transmission Control Module																																																									
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																									
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																									
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2004	ALL	Body	ISU																																																										
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2005	ALL	Powertrain	Transmission Control Module																																																											
L	2005	ALL	Chassis	Anti-lock Brake System																																																											
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2005	ALL	Body	ISU																																																										
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																											
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																											
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2006	ALL	Body	ISU																																																										
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																											
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																											
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																											
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector																																																											
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
L	2007	ALL	Chassis	Electronic Brake Control Module																																																											
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2007	ALL	Body	ISU																																																										
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																											
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																											
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
L	2008	ALL	Chassis	Electronic Brake Control Module																																																											
L	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2008	ALL	Body	ISU																																																										
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																											
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																											
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
L	2009	ALL	Chassis	Electronic Brake Control Module																																																											
L	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2009	ALL	Body	ISU																																																										
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																											
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																											
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
L	2010	ALL	Chassis	Electronic Brake Control Module																																																											
L	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2010	ALL	Body	ISU																																																										
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																										
L	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																										
L	2011	ALL	Chassis	Electronic Brake Control Module																																																										
L	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2011	ALL	Body	ISU																																																										
M	2004	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2004	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2004	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2004	ALL	Chassis	Anti-lock Brake System																																																										
M	2004	ALL	Body	Remote Function Actuation																															V																												
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2005	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2005	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2005	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2005	ALL	Chassis	Anti-lock Brake System																																																										
M	2005	ALL	Body	Remote Function Actuation																															V																												
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2006	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2006	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2006	ALL	Chassis	Anti-lock Brake System																																																										
M	2006	ALL	Body	Remote Function Actuation																															V																												
M	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2007	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2007	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2007	ALL	Chassis	Anti-lock Brake System																																																										
M	2007	ALL	Body	Remote Function Actuation																															V																												
M	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2008	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2008	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2008	ALL	Chassis	Anti-lock Brake System																																																										
M	2008	ALL	Body	Remote Function Actuation																															V																												
M	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2009	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2009	ALL	Chassis	Anti-lock Brake System																																																										
M	2009	ALL	Body	Remote Function Actuation																															V																												
M	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
M	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
M	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
M	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2010	Spark	Powertrain	Transmission Control Module																																																										
M	2010	Spark	Chassis	Electronic Brake Control Module																																																										
M	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2010	Spark	Chassis	Electric Power Steering Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
M	2010	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
M	2010	Spark	Body	Passenger Presence Module																															V																										
M	2010	Spark	Body	Instrument Cluster																																																								
M	2011	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																								
M	2011	Caprice	Powertrain	Transmission Control Module																																																								
M	2011	Caprice	Powertrain	Fuel Pump Control Module																																																								
M	2011	Caprice	Chassis	Electronic Brake Control Module																																																								
M	2011	Caprice	Body	Body Control Module																																																								
M	2011	Caprice	Body	HVAC Control Module																																											V													
M	2011	Caprice	Body	Instrument Panel Cluster																																																								
M	2011	Caprice	Body	Passenger Presence System																																																								
M	2011	Caprice	Body	Radio																																																								
M	2011	Caprice	Body	Remote Control Door Lock Receiver																																																								
M	2011	Caprice	Body	Supplemental Inflatable Restraint																																																								
M	2011	Caprice	Body	Theft Deterrent Module																																																								
M	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
M	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
M	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
M	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
M	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																								
M	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																								
M	2011	Spark	Powertrain	Transmission Control Module																																																								
M	2011	Spark	Chassis	Electronic Brake Control Module																																																								
M	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
M	2011	Spark	Chassis	Electric Power Steering Control Module																																																								
M	2011	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
M	2011	Spark	Body	Passenger Presence Module																															V																										
M	2011	Spark	Body	Instrument Cluster																																																								
M	2012	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																								
M	2012	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																								
M	2012	Caprice	Powertrain	Transmission Control Module																																																								
M	2012	Caprice	Powertrain	Fuel Pump Control Module																																																								
M	2012	Caprice	Chassis	Electronic Brake Control Module																																																								
M	2012	Caprice	Body	Body Control Module																																																								
M	2012	Caprice	Body	HVAC Control Module																																											V													
M	2012	Caprice	Body	Instrument Panel Cluster																																																								
M	2012	Caprice	Body	Passenger Presence System																																																								
M	2012	Caprice	Body	Radio																																																								
M	2012	Caprice	Body	Remote Control Door Lock Receiver																																																								
M	2012	Caprice	Body	Supplemental Inflatable Restraint																									V	V																															
M	2012	Caprice	Body	Theft Deterrent Module																																																								
M	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
M	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
M	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
M	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
M	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																								
M	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
M	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																								
M	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																								
M	2012	Spark	Powertrain	Transmission Control Module																																																								
M	2012	Spark	Chassis	Electronic Brake Control Module																																																								
M	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
M	2012	Spark	Chassis	Electric Power Steering Control Module																																																								
M	2012	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V	V																										
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																											
M	2012	Spark	Body	Passenger Presence Module																															V																									
M	2012	Spark	Body	Instrument Cluster																																																								
M	2013	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																								
M	2013	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																								
M	2013	Caprice	Powertrain	Transmission Control Module																																																								
M	2013	Caprice	Powertrain	Fuel Pump Control Module																																																								
M	2013	Caprice	Chassis	Electronic Brake Control Module																																																								
M	2013	Caprice	Body	Body Control Module																																																								
M	2013	Caprice	Body	HVAC Control Module																																										V														
M	2013	Caprice	Body	Instrument Panel Cluster																																																								
M	2013	Caprice	Body	Passenger Presence System																																																								
M	2013	Caprice	Body	Radio																																																								
M	2013	Caprice	Body	Remote Control Door Lock Receiver																																																								
M	2013	Caprice	Body	Supplemental Inflatable Restraint																									V	V																														
M	2013	Caprice	Body	Theft Deterrent Module																																																								
M	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
M	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																								
M	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
M	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																								
M	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																								
M	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																								
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																				V																																				
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																				V																																				
M	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																								
M	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																								
M	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																								
M	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																								
M	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
M	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
M	2013	Spark	Powertrain	Fuel Injector Control Module																																																								
M	2013	Spark	Chassis	Electronic Brake Control Module																																																								
M	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
M	2013	Spark	Chassis	Power Steering Control Module																																																								
M	2013	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
M	2013	Spark	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V				V																			V					V								
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V																											
M	2013	Spark	Body	Passenger Presence Module																															V																									
M	2013	Spark	Body	Instrument Cluster																																V																								
M	2013	Spark	Body	Radio																																																								
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
M	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
M	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																				V																																					
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																				V																																					
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2014	Spark	Chassis	Power Steering Control Module																																																										
M	2014	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
M	2014	Spark	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V				V																			V					V									
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																
M	2014	Spark	Body	Passenger Presence Module																																V																									
M	2014	Spark	Body	Instrument Cluster																																	V																							
M	2014	Spark	Body	Radio																																																									
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																			
M	2014	Spark	Body	Keyless Entry Control Module																																																									
M	2014	Spark EV	Powertrain	Engine Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module										V																																															
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																											V													
M	2014	Spark EV	Powertrain	Drive Motor Control Module																																																									
M	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																									
M	2014	Spark EV	Chassis	Electronic Brake Control Module																																																									
M	2014	Spark EV	Chassis	Parking Brake Control Module																																																									
M	2014	Spark EV	Chassis	Power Steering Control Module			V																																																						
M	2014	Spark EV	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V		V	V				V																								V									
M	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																									
M	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
M	2014	Spark EV	Body	Passenger Presence Module																																V																									
M	2014	Spark EV	Body	Instrument Cluster																																	V																							
M	2014	Spark EV	Body	Radio																																																									
M	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																			
M	2014	Spark EV	Body	HVAC Control Module																														V													V	V		V									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
M	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																								
M	2014	Spark EV	Body	Coolant Heater Control Module																																																								
M	2014	Spark EV	Body	Keyless Entry Control Module																																																								
M	2014	Spark EV	Body	Battery Charger Control Module																																																								
M	2014	Spark EV	Body	DC Charging Control Module																																																								
M	2014	Spark EV	Body	Battery Energy Control Module																																																								
M	2015	Matiz	Powertrain	1.0L LA2 Engine Control Module																																																								
M	2015	Matiz	Chassis	Electronic Brake Control Module																																																								
M	2015	Matiz	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																															
M	2015	Matiz	Body	Keyless Entry Control Module																																																								
M	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																								
M	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																								
M	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																								
M	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
M	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																								
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																				V																																				
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																															V									
M	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																								
M	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
M	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																								
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																				V																																				
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																															V									
M	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																								
M	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																								
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
M	2015	Spark	Powertrain	Fuel Injector Control Module																																																								
M	2015	Spark	Chassis	Electronic Brake Control Module																																																								
M	2015	Spark	Chassis	Electronic Brake Control Module																																																								
M	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
M	2015	Spark	Chassis	Power Steering Control Module																																																								
M	2015	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
M	2015	Spark	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V				V																				V				V								
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																															
M	2015	Spark	Body	Passenger Presence Module																																V																								
M	2015	Spark	Body	Instrument Cluster																																	V																							
M	2015	Spark	Body	Instrument Cluster																																																								
M	2015	Spark	Body	Tire Pressure Indicator Module																																																	V							
M	2015	Spark	Body	Radio																																																								
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
M	2015	Spark	Body	Keyless Entry Control Module																																																								
M	2015	Spark EV	Powertrain	Engine Control Module																																																								
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module										V																																														
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																											V													
M	2015	Spark EV	Powertrain	Drive Motor Control Module																																																								
M	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
M	2015	Spark EV	Chassis	Electronic Brake Control Module																																																								
M	2015	Spark EV	Chassis	Parking Brake Control Module																																																								
M	2015	Spark EV	Chassis	Power Steering Control Module			V																																																					
M	2015	Spark EV	Body	Body Control Module						V	V	V		V	V	V	V	V		V		V	V				V																									V								
M	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
M	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
M	2015	Spark EV	Body	Passenger Presence Module																																V																								
M	2015	Spark EV	Body	Instrument Cluster																																	V																							
M	2015	Spark EV	Body	Radio																																																								
M	2015	Spark EV	Body	HVAC Control Module																															V													V	V		V									
M	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																								
M	2015	Spark EV	Body	Coolant Heater Control Module																																																								
M	2015	Spark EV	Body	Keyless Entry Control Module																																																								
M	2015	Spark EV	Body	Battery Charger Control Module																																																								
M	2015	Spark EV	Body	DC Charging Control Module																																																								
M	2015	Spark EV	Body	Battery Energy Control Module																																																								
M	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																								
M	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																								
M	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																								
M	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																								
M	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																								
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																				V																																				
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																								
M	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
M	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																								
M	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
M	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																								
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
M	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																								
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																				V																																				
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																								
M	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																								
M	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																								
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																				V																																				
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																								
M	2016	Spark	Powertrain	Fuel Injector Control Module																																																								
M	2016	Spark	Chassis	Electronic Brake Control Module																																																								
M	2016	Spark	Chassis	Electronic Brake Control Module																																																								
M	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
M	2016	Spark	Chassis	Power Steering Control Module																																																								
M	2016	Spark	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
M	2016	Spark	Body	Body Control Module						V	V	V		V	V		V	V	V		V	V	V	V			V	V																									V								
M	2016	Spark	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V		V	V				V																					V						V						
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																															
M	2016	Spark	Body	Instrument Cluster																																V																								
M	2016	Spark	Body	Instrument Cluster																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
M	2016	Spark	Body	Radio																																																								
M	2016	Spark	Body	Telematics Communication Interface Control Module																																	V	V	V																					
M	2016	Spark	Body	Keyless Entry Control Module																																																								
M	2016	Spark EV	Powertrain	Engine Control Module																																																								
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module										V																																														
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																											V													
M	2016	Spark EV	Powertrain	Drive Motor Control Module																																																								
M	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								
M	2016	Spark EV	Chassis	Electronic Brake Control Module																																																								
M	2016	Spark EV	Chassis	Parking Brake Control Module																																																								
M	2016	Spark EV	Chassis	Power Steering Control Module			V																																																					
M	2016	Spark EV	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V		V	V				V																										V						
M	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
M	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
M	2016	Spark EV	Body	Passenger Presence Module																																V																								
M	2016	Spark EV	Body	Instrument Cluster																																	V																							
M	2016	Spark EV	Body	Radio																																																								
M	2016	Spark EV	Body	Telematics Communication Interface Control Module																																	V	V	V																					
M	2016	Spark EV	Body	HVAC Control Module																														V												V	V		V											
M	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																								
M	2016	Spark EV	Body	Coolant Heater Control Module																																																								
M	2016	Spark EV	Body	Keyless Entry Control Module																																																								
M	2016	Spark EV	Body	Frontview Camera Module																																																								
M	2016	Spark EV	Body	Battery Charger Control Module																																																								
M	2016	Spark EV	Body	DC Charging Control Module																																																								
M	2016	Spark EV	Body	Battery Energy Control Module																																																								
N	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
N	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
N	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																								
N	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
N	2004	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																								
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																								
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																								
N	2004	Optra	Body	Remote Function Actuation																														V																										
N	2004	Optra	Body	Supplemental Inflatable Restraint																																																								
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
N	2004	Classic	Chassis	Anti-lock Brake System																																																								
N	2004	Classic	Body	Body Control Module																														V																										
N	2004	Classic	Body	Radio																																																								
N	2004	Classic	Body	Remote Function Actuation																																																								
N	2004	Classic	Body	Supplemental Inflatable Restraint																																																								
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																								
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Transmission Control Module																																																								
N	2004	Alero (Export)	Chassis	Anti-lock Brake System																																																								
N	2004	Alero (Export)	Body	Body Control Module																																																								
N	2004	Alero (Export)	Body	Instrument Panel Cluster																																																								
N	2004	Alero (Export)	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
N	2004	Alero (Export)	Body	Supplemental Inflatable Restraint																																																									
N	2004	Alero (Export)	Body	Vehicle Theft Deterrent																																																										
N	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
N	2005	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2005	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
N	2005	Optra	Body	Remote Function Actuation																															V																												
N	2005	Optra	Body	Supplemental Inflatable Restraint																																																										
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
N	2005	Classic	Chassis	Anti-lock Brake System																																																										
N	2005	Classic	Body	Body Control Module																															V																												
N	2005	Classic	Body	Radio																																																										
N	2005	Classic	Body	Remote Function Actuation																																																										
N	2005	Classic	Body	Supplemental Inflatable Restraint																																																										
N	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
N	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2006	ALL	Body	Remote Function Actuation																															V																												
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																										
N	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																										
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																										
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																										
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																										
N	2007	ALL	Chassis	Tire Pressure Monitor																																																										
N	2007	ALL	Body	Remote Function Actuation																															V																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
N	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
N	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																										
N	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																																																										
N	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																										
N	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2008	ALL	Chassis	Tire Pressure Monitor																																																										
N	2008	ALL	Body	Remote Function Actuation																														V																												
N	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
N	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																										
N	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																										
N	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2009	ALL	Chassis	Tire Pressure Monitor																																																										
N	2009	ALL	Body	Remote Function Actuation																														V																												
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2010	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
N	2010	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2010	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																										
N	2010	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2010	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2010	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2010	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2010	ALL	Chassis	Tire Pressure Monitor																																																										
N	2010	ALL	Body	Remote Function Actuation																														V																												
N	2010	ALL	Body	Remote Function Actuation																																																										
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
N	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
N	2011	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																									
N	2011	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																									
N	2011	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
N	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
N	2011	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																									
N	2011	ALL	Powertrain	Transmission Control Module 5 Speed																																																									
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																									
N	2011	ALL	Chassis	Tire Pressure Monitor																																																									
N	2011	ALL	Body	Remote Function Actuation																														V																											
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2012	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
N	2012	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
N	2012	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																									
N	2012	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																									
N	2012	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
N	2012	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																									
N	2012	ALL	Powertrain	Transmission Control Module 5 Speed																																																									
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																									
N	2012	ALL	Chassis	Tire Pressure Monitor																																																									
N	2012	ALL	Body	Remote Function Actuation																														V																											
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2013	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
N	2013	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
N	2013	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																									
N	2013	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																									
N	2013	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
N	2013	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																									
N	2013	ALL	Powertrain	Transmission Control Module 5 Speed																																																									
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																									
N	2013	ALL	Chassis	Tire Pressure Monitor																																																									
N	2013	ALL	Body	Remote Function Actuation																														V																											
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																				
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
N	2014	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																				V																																				
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																									
N	2014	Caprice	Powertrain	(2) 6.0L L77 Chassis Control Module																																																									
N	2014	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																									
N	2014	Caprice	Chassis	Electronic Brake Control Module					V																																																				
N	2014	Caprice	Chassis	Parking Brake Control Module																																																									
N	2014	Caprice	Chassis	Power Steering Control Module	V																																																								
N	2014	Caprice	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
N	2014	Caprice	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V				V																								V							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
N	2014	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
N	2014	Caprice	Body	Passenger Presence Module																																V																								
N	2014	Caprice	Body	Instrument Cluster																																	V																						
N	2014	Caprice	Body	Radio Controls																																	V																						
N	2014	Caprice	Body	HVAC Controls																																																							
N	2014	Caprice	Body	Headlamp Control Module																																																							
N	2014	Caprice	Body	Trailer Interface Control Module																																																							
N	2014	Caprice	Body	Radio																																																							
N	2014	Caprice	Body	HVAC Control Module																														V													V	V	V		V									
N	2014	Caprice	Body	Parking Assist Control Module																																	V																						
N	2014	Caprice	Body	Frontview Camera Module																																																							
N	2014	Caprice	Body	Steering Column Lock Control Module																																																							
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																			
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																							
N	2015	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																							
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																				V																																			
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																							
N	2015	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																							
N	2015	Caprice	Powertrain	Fuel Injector Control Module																																																							
N	2015	Caprice	Chassis	Electronic Brake Control Module					V																																																		
N	2015	Caprice	Chassis	Parking Brake Control Module																																																							
N	2015	Caprice	Chassis	Power Steering Control Module	V																																																						
N	2015	Caprice	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
N	2015	Caprice	Chassis	Suspension Control Module																																																							
N	2015	Caprice	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V				V																															
N	2015	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
N	2015	Caprice	Body	Passenger Presence Module																																V																								
N	2015	Caprice	Body	Instrument Cluster																																	V																						
N	2015	Caprice	Body	Head-Up Display Module																																																						
N	2015	Caprice	Body	Radio Controls																																	V																						
N	2015	Caprice	Body	HVAC Controls																																																						
N	2015	Caprice	Body	Headlamp Control Module																																																						
N	2015	Caprice	Body	Trailer Interface Control Module																																																						
N	2015	Caprice	Body	Radio																																																						
N	2015	Caprice	Body	Telematics Communication Interface Control Module																																		V	V	V																			
N	2015	Caprice	Body	HVAC Control Module																														V													V	V	V		V									
N	2015	Caprice	Body	Right Side Object Detection Control Module																																																						
N	2015	Caprice	Body	Left Side Object Detection Control Module																																																						
N	2015	Caprice	Body	Parking Assist Control Module																																	V																						
N	2015	Caprice	Body	Frontview Camera Module																																																						
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																			
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																							
N	2016	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																							
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																				V																																			
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																							
N	2016	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																							
N	2016	Caprice	Powertrain	Fuel Injector Control Module																																																							
N	2016	Caprice	Chassis	Electronic Brake Control Module					V																																																		
N	2016	Caprice	Chassis	Parking Brake Control Module																																																							
N	2016	Caprice	Chassis	Power Steering Control Module	V																																																						
N	2016	Caprice	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
N	2016	Caprice	Chassis	Suspension Control Module																																																								
N	2016	Caprice	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V				V																							V								
N	2016	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
N	2016	Caprice	Body	Passenger Presence Module																															V																								
N	2016	Caprice	Body	Instrument Cluster																																V																							
N	2016	Caprice	Body	Head-Up Display Module																																																						
N	2016	Caprice	Body	Radio Controls																																V																							
N	2016	Caprice	Body	HVAC Controls																																																						
N	2016	Caprice	Body	Trailer Interface Control Module																																																						
N	2016	Caprice	Body	Radio																																																						
N	2016	Caprice	Body	Telematics Communication Interface Control Module																																	V	V	V																				
N	2016	Caprice	Body	HVAC Control Module																														V												V	V	V		V								
N	2016	Caprice	Body	Seat Memory Control Module - Driver																																																						
N	2016	Caprice	Body	Right Side Object Detection Control Module																																																						
N	2016	Caprice	Body	Left Side Object Detection Control Module																																																						
N	2016	Caprice	Body	Parking Assist Control Module																																V																							
N	2016	Caprice	Body	Frontview Camera Module																																																						
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																						
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																						
P	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																						
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																						
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																						
P	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																						
P	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																						
P	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																						
P	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																						
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																						
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																						
P	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																						
P	2010	Cruze	Chassis	Electronic Brake Control Module																																																						
P	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																						
P	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
P	2010	Cruze	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V																															
P	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
P	2010	Cruze	Body	Passenger Presence Module																																V																							
P	2010	Cruze	Body	Instrument Cluster																																V																							
P	2010	Cruze	Body	Trailer Interface Control Module																																V																							
P	2010	Cruze	Body	Radio																																																						
P	2010	Cruze	Body	Multimedia Player Interface Module																																V																							
P	2010	Cruze	Body	Mobile Telephone Control Module																																V																							
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																		
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
P	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																														V												V	V	V	V	V							
P	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																														V												V	V	V	V	V							
P	2010	Cruze	Body	Keyless Entry Control Module																																																						
P	2010	Cruze	Body	Parking Assist Control Module																																V																							
P	2010	Cruze	Body	Steering Column Lock Control Module																																																						
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																			V
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																	V					V
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																						
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																								
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																								
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																								
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																								
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																								
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																								
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																								
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																								
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																								
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																				
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																								
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																								
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																								
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																								
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2011	Cruze	Chassis	Electronic Brake Control Module																																																								
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
P	2011	Cruze	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																										V						
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
P	2011	Cruze	Body	Passenger Presence Module																																V																								
P	2011	Cruze	Body	Instrument Cluster																																	V																						
P	2011	Cruze	Body	Trailer Interface Control Module																																	V																						
P	2011	Cruze	Body	Radio																																																							
P	2011	Cruze	Body	Multimedia Player Interface Module																																	V																						
P	2011	Cruze	Body	Mobile Telephone Control Module																																	V																						
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																														V											V	V	V	V	V									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																														V											V	V	V	V	V									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																														V											V	V	V	V	V									
P	2011	Cruze	Body	Keyless Entry Control Module																																																								
P	2011	Cruze	Body	Parking Assist Control Module																																	V																						
P	2011	Cruze	Body	Steering Column Lock Control Module																																																								
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																								
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																								
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																								
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																								
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																								
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																								
P	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																								
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
P	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																								
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																								
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																								
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																								
P	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
P	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																				
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
P	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																								
P	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																								
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																								
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																								
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																								
P	2012	Cruze	Chassis	Electronic Brake Control Module																																																								
P	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
P	2012	Cruze	Body	Body Control Module Hatchback						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																										V							
P	2012	Cruze	Body	Body Control Module Sedan						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																										V							
P	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
P	2012	Cruze	Body	Passenger Presence Module																															V																									
P	2012	Cruze	Body	Instrument Cluster																																V																								
P	2012	Cruze	Body	Trailer Interface Control Module																																V																								
P	2012	Cruze	Body	Radio																																																								
P	2012	Cruze	Body	Multimedia Player Interface Module																																V																								
P	2012	Cruze	Body	Mobile Telephone Control Module																																V																								
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
P	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																														V													V	V	V	V	V									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																														V													V	V	V	V	V									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																														V													V	V	V	V	V									
P	2012	Cruze	Body	Keyless Entry Control Module																																																								
P	2012	Cruze	Body	Parking Assist Control Module																																V																								
P	2012	Cruze	Body	Steering Column Lock Control Module																																																								
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																									
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																				
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																				V		
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																							
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																			V	V	
P	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																							
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																							
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																							
P	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																							
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																							
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																							
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																							
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																							
P	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																							
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																							
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																							
P	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																							
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																							
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																							
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																							
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																							
P	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																							
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																							
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																							
P	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																							
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																				
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																							
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																				V		
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																							
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																			V	V	
P	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																							
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																				V																												V							
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																															V							
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																				V		
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																						
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																			V	V	
P	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																						
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																						
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																						
P	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																						
P	2013	Cruze	Chassis	Electronic Brake Control Module																																																						
P	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																						
P	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
P	2013	Cruze	Body	Body Control Module Hatchback						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V					
P	2013	Cruze	Body	Body Control Module Sedan						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V					
P	2013	Cruze	Body	Body Control Module Station Wagon						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V					
P	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																						
P	2013	Cruze	Body	Passenger Presence Module																																V																						
P	2013	Cruze	Body	Instrument Cluster																																	V																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2013	Cruze	Body	Trailer Interface Control Module																																V																								
P	2013	Cruze	Body	Radio																																																								
P	2013	Cruze	Body	Digital Radio Receiver Control Module																																																								
P	2013	Cruze	Body	Multimedia Player Interface Module																																V																								
P	2013	Cruze	Body	Mobile Telephone Control Module																																V																								
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																		
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																													V												V	V	V	V	V								
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																													V												V	V	V	V									
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																													V												V	V	V	V	V								
P	2013	Cruze	Body	Front Seat Heating Control Module																																					V	V																
P	2013	Cruze	Body	Keyless Entry Control Module																																																							
P	2013	Cruze	Body	Right Side Object Detection Control Module																																																							
P	2013	Cruze	Body	Left Side Object Detection Control Module																																																							
P	2013	Cruze	Body	Parking Assist Control Module																																V																							
P	2013	Cruze	Body	Steering Column Lock Control Module																																																							
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																				
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																							
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																							
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																							
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																				
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																							
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																				V		
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																						
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																			V	V		
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																						
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																						
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																						
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																						
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																						
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																						
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																						
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																						
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																				V		
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																						
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																			V	V		
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																						
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																				V																																				
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																							
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																							
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																							
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																							
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																							
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																							
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																							
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																							
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																							
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																							
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																							
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																									
P	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																				
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																					V		
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																				V	V		
P	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																				V																											V									
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																														V									
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																					V		
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																				V	V		
P	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																					V		
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																				V	V		
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																					V			
P	2014	Cruze	Powertrain	Fuel Injector Control Module																																																									
P	2014	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2014	Cruze	Chassis	Power Steering Control Module	V	V	V																																																							
P	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
P	2014	Cruze	Body	Body Control Module Hatchback						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V								
P	2014	Cruze	Body	Body Control Module Sedan						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V								
P	2014	Cruze	Body	Body Control Module Station Wagon						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V								
P	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
P	2014	Cruze	Body	Passenger Presence Module																																V																									
P	2014	Cruze	Body	Instrument Cluster																																	V																							
P	2014	Cruze	Body	Trailer Interface Control Module																																	V																							
P	2014	Cruze	Body	Radio																																																								
P	2014	Cruze	Body	Digital Radio Receiver Control Module																																																								
P	2014	Cruze	Body	Multimedia Player Interface Module																																	V																							
P	2014	Cruze	Body	Mobile Telephone Control Module																																	V																							
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
P	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V								
P	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																														V												V	V	V	V									
P	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V								
P	2014	Cruze	Body	Front Seat Heating Control Module																																						V	V																	
P	2014	Cruze	Body	Keyless Entry Control Module																																																								
P	2014	Cruze	Body	Right Side Object Detection Control Module																																																								
P	2014	Cruze	Body	Left Side Object Detection Control Module																																																								
P	2014	Cruze	Body	Parking Assist Control Module																																	V																							
P	2014	Cruze	Body	Steering Column Lock Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																						
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																				V																																						
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																						
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																				V																												V									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																															V									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																							V		
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																					V	V		
P	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																								
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																						V		
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																					V	V		
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																								
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																		V	V					
P	2015	Cruze	Powertrain	Fuel Injector Control Module																																																								
P	2015	Cruze	Chassis	Electronic Brake Control Module																																																								
P	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2015	Cruze	Chassis	Power Steering Control Module	V	V	V																																																						
P	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
P	2015	Cruze	Body	Body Control Module Hatchback						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V							
P	2015	Cruze	Body	Body Control Module Sedan						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V							
P	2015	Cruze	Body	Body Control Module Station Wagon						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																								V							
P	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
P	2015	Cruze	Body	Passenger Presence Module																																V																								
P	2015	Cruze	Body	Instrument Cluster																																	V																							
P	2015	Cruze	Body	Trailer Interface Control Module																																	V																							
P	2015	Cruze	Body	Radio																																																								
P	2015	Cruze	Body	Digital Radio Receiver Control Module																																																								
P	2015	Cruze	Body	Multimedia Player Interface Module																																	V																							
P	2015	Cruze	Body	Mobile Telephone Control Module																																	V																							
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
P	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																														V											V	V	V	V	V								
P	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																														V											V	V	V	V									
P	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																														V											V	V	V	V	V								
P	2015	Cruze	Body	Front Seat Heating Control Module																																					V	V																	
P	2015	Cruze	Body	Keyless Entry Control Module																																																								
P	2015	Cruze	Body	Right Side Object Detection Control Module																																																								
P	2015	Cruze	Body	Left Side Object Detection Control Module																																																								
P	2015	Cruze	Body	Parking Assist Control Module																																	V																							
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																				
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																								
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																								
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																				
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																				V																														V						
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																		V						
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2016	Cruze	Powertrain	Fuel Injector Control Module																																																								
P	2016	Cruze	Powertrain	Chassis Control Module																																																				V	V			
P	2016	Cruze	Chassis	Electronic Brake Control Module																																																								
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2016	Cruze	Chassis	Power Steering Control Module																																																								
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
P	2016	Cruze	Body	Body Control Module Hatchback						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																												V					
P	2016	Cruze	Body	Body Control Module Sedan						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																												V					
P	2016	Cruze	Body	Body Control Module Station Wagon						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																												V					
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
P	2016	Cruze	Body	Passenger Presence Module																																V																								
P	2016	Cruze	Body	Instrument Cluster																																	V																							
P	2016	Cruze	Body	Trailer Interface Control Module																																	V																							
P	2016	Cruze	Body	Radio Other																																																								
P	2016	Cruze	Body	Radio (UF7)																																																								
P	2016	Cruze	Body	Multimedia Player Interface Module																																	V																							
P	2016	Cruze	Body	Mobile Telephone Control Module																																	V																							
P	2016	Cruze	Body	Telematics Communication Interface Control Module																																		V	V	V																				
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																														V													V	V	V	V										
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																														V													V	V	V	V										
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																														V													V	V	V											
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																														V													V	V	V	V										
P	2016	Cruze	Body	Front Seat Heating Control Module																																					V	V																		
P	2016	Cruze	Body	Keyless Entry Control Module																																																								
P	2016	Cruze	Body	Right Side Object Detection Control Module																																																								
P	2016	Cruze	Body	Left Side Object Detection Control Module																																																								
P	2016	Cruze	Body	Parking Assist Control Module																																V																								
P	2016	Cruze	Body	Steering Column Lock Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2011	Volt	Powertrain	Engine Control Module																																																								
R	2011	Volt	Powertrain	Trasmission Control Module																																																								
R	2011	Volt	Powertrain	Fuel Pump Control Module																																																								
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module										V																																		V										V	V
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module 2																																												V											
R	2011	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2011	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2011	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																								
R	2011	Volt	Chassis	Electronic Brake Control Module																																																								
R	2011	Volt	Chassis	Parking Brake Control Module																																																								
R	2011	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																								
R	2011	Volt	Chassis	Power Steering Control Module	V	V																																																						
R	2011	Volt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
R	2011	Volt	Body	Body Control Module						V	V	V	V	V	V	V	V		V		V	V	V	V	V		V	V																											V					
R	2011	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
R	2011	Volt	Body	Passenger Presence Module																															V																									
R	2011	Volt	Body	Instrument Cluster																																V																								
R	2011	Volt	Body	Radio																																																								
R	2011	Volt	Body	Digital Radio Receiver Control Module																																																								
R	2011	Volt	Body	Mobile Telephone Control Module																																V																								
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V																					
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
R	2011	Volt	Body	Remote Heater and Air Conditioning Control Module																															V												V	V	V	V	V									
R	2011	Volt	Body	Electric A/C Compressor Control Module																																																								
R	2011	Volt	Body	Coolant Heater Control Module																																																								
R	2011	Volt	Body	Keyless Entry Control Module																																																								
R	2011	Volt	Body	Parking Assist Control Module																																V																								
R	2011	Volt	Body	Steering Column Lock Control Module																																																								
R	2011	Volt	Body	Battery Charger Control Module																																																								
R	2011	Volt	Body	Battery Energy Control Module																																																								
R	2012	Volt	Powertrain	Engine Control Module																																																								
R	2012	Volt	Powertrain	Trasmission Control Module																																																								
R	2012	Volt	Powertrain	Fuel Pump Control Module																																																								
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module										V																																		V										V	V
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module 2																																												V											
R	2012	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2012	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2012	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																								
R	2012	Volt	Chassis	Electronic Brake Control Module																																																								
R	2012	Volt	Chassis	Parking Brake Control Module																																																								
R	2012	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																								
R	2012	Volt	Chassis	Power Steering Control Module	V	V																																																						
R	2012	Volt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
R	2012	Volt	Body	Body Control Module						V	V	V	V	V	V	V	V		V		V	V	V	V	V		V	V																											V					
R	2012	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
R	2012	Volt	Body	Passenger Presence Module																															V																									
R	2012	Volt	Body	Instrument Cluster																																V																								
R	2012	Volt	Body	Radio																																																								
R	2012	Volt	Body	Digital Radio Receiver Control Module																																																								
R	2012	Volt	Body	Mobile Telephone Control Module																																V																								
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
R	2012	Volt	Body	Remote Heater and Air Conditioning Control Module																														V											V	V	V	V	V								
R	2012	Volt	Body	Electric A/C Compressor Control Module																																																					
R	2012	Volt	Body	Coolant Heater Control Module																																																					
R	2012	Volt	Body	Keyless Entry Control Module																																																					
R	2012	Volt	Body	Parking Assist Control Module																																V																						
R	2012	Volt	Body	Steering Column Lock Control Module																																																					
R	2012	Volt	Body	Battery Charger Control Module																																																					
R	2012	Volt	Body	Battery Energy Control Module																																																					
R	2013	Volt	Powertrain	Engine Control Module																																																					
R	2013	Volt	Powertrain	Trasmission Control Module																																																					
R	2013	Volt	Powertrain	Fuel Pump Control Module																																																					
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module										V																																V									V	V
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module 2																																										V										
R	2013	Volt	Powertrain	Drive Motor Control Module 1																																																				
R	2013	Volt	Powertrain	Drive Motor Control Module 2																																																				
R	2013	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																				
R	2013	Volt	Chassis	Electronic Brake Control Module																																																				
R	2013	Volt	Chassis	Parking Brake Control Module																																																				
R	2013	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																				
R	2013	Volt	Chassis	Power Steering Control Module	V	V																																																		
R	2013	Volt	Chassis	Steering Wheel Angle Sensor Module				V	V																																															
R	2013	Volt	Body	Body Control Module						V	V	V		V	V	V	V		V		V	V	V	V	V		V	V																							V					
R	2013	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																					
R	2013	Volt	Body	Passenger Presence Module																																V																				
R	2013	Volt	Body	Instrument Cluster																																	V																			
R	2013	Volt	Body	Radio																																																				
R	2013	Volt	Body	Digital Radio Receiver Control Module																																																				
R	2013	Volt	Body	Multimedia Player Interface Module																																	V																			
R	2013	Volt	Body	Mobile Telephone Control Module																																	V																			
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																
R	2013	Volt	Body	HVAC Control Module																														V											V	V	V	V	V								
R	2013	Volt	Body	Electric A/C Compressor Control Module																																																				
R	2013	Volt	Body	Coolant Heater Control Module																																																				
R	2013	Volt	Body	Front Seat Heating Control Module																																					V	V															
R	2013	Volt	Body	Keyless Entry Control Module																																																				
R	2013	Volt	Body	Parking Assist Control Module																																V																			
R	2013	Volt	Body	Frontview Camera Module																																																				
R	2013	Volt	Body	Steering Column Lock Control Module																																																				
R	2013	Volt	Body	Battery Charger Control Module																																																				
R	2013	Volt	Body	Battery Energy Control Module																																																				
R	2014	Volt	Powertrain	Engine Control Module																																																				
R	2014	Volt	Powertrain	Trasmission Control Module																																																				
R	2014	Volt	Powertrain	Chassis Control Module																																																				
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module										V																																V									V	V
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module 2																																										V										
R	2014	Volt	Powertrain	Drive Motor Control Module 1																																																				
R	2014	Volt	Powertrain	Drive Motor Control Module 2																																																				
R	2014	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																				
R	2014	Volt	Chassis	Electronic Brake Control Module																																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2014	Volt	Chassis	Parking Brake Control Module																																																											
R	2014	Volt	Chassis	Power Steering Control Module	V	V																																																									
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
R	2014	Volt	Body	Body Control Module						V	V	V		V	V	V	V		V		V	V	V	V	V		V	V																							V									
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
R	2014	Volt	Body	Passenger Presence Module																																V																											
R	2014	Volt	Body	Instrument Cluster																																	V																									
R	2014	Volt	Body	Radio																																																										
R	2014	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																				
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
R	2014	Volt	Body	HVAC Control Module																														V													V	V	V	V	V									
R	2014	Volt	Body	Electric A/C Compressor Control Module																																																									
R	2014	Volt	Body	Coolant Heater Control Module																																																									
R	2014	Volt	Body	Front Seat Heating Control Module																																					V	V																			
R	2014	Volt	Body	Keyless Entry Control Module																																																									
R	2014	Volt	Body	Parking Assist Control Module																																V																									
R	2014	Volt	Body	Frontview Camera Module																																																									
R	2014	Volt	Body	Steering Column Lock Control Module																																																									
R	2014	Volt	Body	Battery Charger Control Module																																																									
R	2014	Volt	Body	Battery Energy Control Module																																																									
R	2015	Volt	Powertrain	Engine Control Module																																																									
R	2015	Volt	Powertrain	Trasmission Control Module																																																									
R	2015	Volt	Powertrain	Chassis Control Module																																																									
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module										V																																	V											V	V
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2																																											V												
R	2015	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2015	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																								
R	2015	Volt	Chassis	Electronic Brake Control Module																																																								
R	2015	Volt	Chassis	Parking Brake Control Module																																																								
R	2015	Volt	Chassis	Power Steering Control Module	V	V																																																							
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
R	2015	Volt	Body	Body Control Module						V	V	V		V	V	V	V		V		V	V	V	V	V		V	V																							V									
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
R	2015	Volt	Body	Passenger Presence Module																																V																											
R	2015	Volt	Body	Instrument Cluster																																	V																									
R	2015	Volt	Body	Radio																																																										
R	2015	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2015	Volt	Body	Telematics Communication Interface Control Module																																		V	V	V																				
R	2015	Volt	Body	HVAC Control Module																														V													V	V	V	V	V									
R	2015	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2015	Volt	Body	Coolant Heater Control Module																																																									
R	2015	Volt	Body	Front Seat Heating Control Module																																					V	V																			
R	2015	Volt	Body	Keyless Entry Control Module																																																									
R	2015	Volt	Body	Parking Assist Control Module																																V																									
R	2015	Volt	Body	Frontview Camera Module																																																									
R	2015	Volt	Body	Steering Column Lock Control Module																																																									
R	2015	Volt	Body	Battery Charger Control Module																																																									
R	2015	Volt	Body	Battery Energy Control Module																																																									
R	2016	Volt	Powertrain	Engine Control Module																				V																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module										V																																	V												V
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module 2																																											V											
R	2016	Volt	Powertrain	Drive Motor Control Module 1																																																						
R	2016	Volt	Powertrain	Drive Motor Control Module 2																																																						
R	2016	Volt	Chassis	Electronic Brake Control Module					V																																																	
R	2016	Volt	Chassis	Brake Booster Control Module																																																						
R	2016	Volt	Chassis	Power Steering Control Module			V																																																			
R	2016	Volt	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V		V	V																								V						
R	2016	Volt	Body	Pedestrian Alert Sound Control Module																																																						
R	2016	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
R	2016	Volt	Body	Passenger Presence Module																																V																							
R	2016	Volt	Body	Instrument Cluster																																	V																						
R	2016	Volt	Body	Radio Controls																																																						
R	2016	Volt	Body	HVAC Controls																																																						
R	2016	Volt	Body	Radio																																																						
R	2016	Volt	Body	Amplifier																																																						
R	2016	Volt	Body	Human Machine Interface Control Module																																																						
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																			
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
R	2016	Volt	Body	HVAC Control Module																														V													V	V	V	V								
R	2016	Volt	Body	Electric A/C Compressor Control Module																																																						
R	2016	Volt	Body	Keyless Entry Control Module																																																						
R	2016	Volt	Body	Right Side Object Detection Control Module																																																						
R	2016	Volt	Body	Left Side Object Detection Control Module																																																						
R	2016	Volt	Body	Parking Assist Control Module																																V																							
R	2016	Volt	Body	Frontview Camera Module																																																						
R	2016	Volt	Body	Steering Column Lock Control Module																																																						
R	2016	Volt	Body	Battery Energy Control Module																																																						
R	2016	Volt	Body	Long Range Radar Sensor Module																																																						
S	2004	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																						
S	2004	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																						
S	2004	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																						
S	2004	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																						
S	2004	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																						
S	2004	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																						
S	2004	Aveo	Powertrain	Transmission Control Module																																																						
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																						
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																						
S	2004	Aveo	Body	Supplemental Inflatable Restraint																																																						
S	2004	Aveo	Body	Remote Function Actuation																														V																							
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																						
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																						
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																						
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																						
S	2005	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																						
S	2005	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																						
S	2005	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																						
S	2005	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																						
S	2005	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																						
S	2005	Aveo	Powertrain	Transmission Control Module																																																						
S	2005	Aveo	Chassis	Electronic Brake Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2005	Aveo	Body	Supplemental Inflatable Restraint																																																									
S	2005	Aveo	Body	Remote Function Actuation																														V																												
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																									
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																									
S	2006	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																									
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																									
S	2006	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																									
S	2006	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																									
S	2006	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
S	2006	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2006	Aveo	Body	Supplemental Inflatable Restraint																																																									
S	2006	Aveo	Body	Remote Function Actuation																														V																												
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																									
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																									
S	2007	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																									
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																									
S	2007	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																									
S	2007	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																									
S	2007	Aveo	Powertrain	Transmission Control Module 4 Speed																																																									
S	2007	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
S	2007	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2007	Aveo	Body	Supplemental Inflatable Restraint																																																									
S	2007	Aveo	Body	Remote Function Actuation																														V																												
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																									
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																									
S	2008	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																									
S	2008	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																									
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																									
S	2008	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																									
S	2008	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
S	2008	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																									
S	2008	Aveo	Powertrain	Transmission Control Module																																																									
S	2008	Aveo	Powertrain	Transmission Control Module																																																									
S	2008	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2008	Aveo	Chassis	Tire Pressure Monitor																																																									
S	2008	Aveo	Body	Supplemental Inflatable Restraint																																																									
S	2008	Aveo	Body	Remote Function Actuation																														V																												
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																									
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																									
S	2009	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																									
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																									
S	2009	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																									
S	2009	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2009	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																									
S	2009	Aveo	Powertrain	Transmission Control Module																																																										
S	2009	Aveo	Powertrain	Transmission Control Module																																																										
S	2009	Aveo	Powertrain	Other Auto Transmission System																																																										
S	2009	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2009	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2009	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2009	Aveo	Body	Remote Function Actuation																														V																												
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2010	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2010	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2010	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2010	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2010	Aveo	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
S	2010	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2010	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2010	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2010	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2010	Aveo	Body	Remote Function Actuation																														V																												
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
S	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
S	2010	Sail	Powertrain	Transmission Control Module																																																										
S	2010	Sail	Chassis	Electronic Brake Control Module																																																										
S	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																								V																																	
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2011	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2011	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2011	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2011	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2011	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
S	2011	Aveo	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																										
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2011	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2011	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2011	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2011	Aveo	Body	Remote Function Actuation																														V																												
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
S	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
S	2011	Sail	Powertrain	Transmission Control Module																																																										
S	2011	Sail	Chassis	Electronic Brake Control Module																																																										
S	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																								V																																	
S	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																									
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																					
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																					
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																				V																																					
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																					
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
S	2012	Aveo	Powertrain	Fuel Pump Control Module																																																										
S	2012	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	Aveo	Chassis	Electric Power Steering Control Module																																																										
S	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
S	2012	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2012	Aveo	Body	Body Control Module Hatchback						V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V								
S	2012	Aveo	Body	Body Control Module Sedan						V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V								
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2012	Aveo	Body	Passenger Presence Module																																V																									
S	2012	Aveo	Body	Instrument Cluster																																	V																							
S	2012	Aveo	Body	Radio																																																									
S	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																									
S	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																												V												
S	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V												
S	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																												V												
S	2012	Aveo	Body	Front Seat Heating Control Module																																					V	V																			
S	2012	Aveo	Body	Remote Function Actuation																														V																										
S	2012	Aveo	Body	Parking Assist Control Module																																																								
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																									
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																									
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																									
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																									
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																									
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																									
S	2012	Sail	Powertrain	Transmission Control Module																																																									
S	2012	Sail	Chassis	Electronic Brake Control Module																																																									
S	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																															
S	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																									
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																				
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																				V																																				
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																				
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
S	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
S	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																									
S	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
S	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																				
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																				V																																				
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
S	2013	Aveo	Powertrain	Fuel Injector Control Module																																																									
S	2013	Aveo	Powertrain	Fuel Pump Control Module																																																									
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2013	Aveo	Chassis	Electric Power Steering Control Module																																																									
S	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
S	2013	Aveo	Body	Body Control Module Hatchback						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																								V							
S	2013	Aveo	Body	Body Control Module Sedan						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																								V							
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2013	Aveo	Body	Passenger Presence Module																																V																								
S	2013	Aveo	Body	Instrument Cluster																																	V																						
S	2013	Aveo	Body	Radio																																																								
S	2013	Aveo	Body	Telematics Communication Interface Control Module																																		V	V	V	V																		

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																													V													
S	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																													V													
S	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																													V													
S	2013	Aveo	Body	Front Seat Heating Control Module																																						V	V																				
S	2013	Aveo	Body	Remote Function Actuation																															V																											
S	2013	Aveo	Body	Parking Assist Control Module																																																										
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2013	Sail	Powertrain	Transmission Control Module																																																										
S	2013	Sail	Chassis	Electronic Brake Control Module																																																										
S	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																	
S	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																						
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																				V																																						
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
S	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																				V																																						
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																						
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
S	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
S	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
S	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																						
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																				V																																						
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																				V																																				
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																							
S	2014	Aveo	Powertrain	Chassis Control Module																																																							
S	2014	Aveo	Powertrain	Fuel Injector Control Module																																																							
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																							
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																							
S	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																							
S	2014	Aveo	Chassis	Power Steering Control Module																																																							
S	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
S	2014	Aveo	Body	Body Control Module Hatchback						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V						
S	2014	Aveo	Body	Body Control Module Sedan						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V						
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																														
S	2014	Aveo	Body	Instrument Cluster																																V																							
S	2014	Aveo	Body	Radio																																																							
S	2014	Aveo	Body	Telematics Communication Interface Control Module																																	V	V	V	V																			
S	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																												V									
S	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V									
S	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																												V									
S	2014	Aveo	Body	Front Seat Heating Control Module																																					V	V																
S	2014	Aveo	Body	Keyless Entry Control Module																																																						
S	2014	Aveo	Body	Parking Assist Control Module																																																						
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																						
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																						
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																						
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																						
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																						
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																						
S	2014	Sail	Powertrain	Transmission Control Module																																																						
S	2014	Sail	Chassis	Electronic Brake Control Module																																																						
S	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																														
S	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																						
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																			
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																						
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																				V																																			
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																						
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																						
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																						
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																						
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																						
S	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																						
S	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																						
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																						
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																						
S	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																						
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																				V																																			
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																						
S	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																						
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																			
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																								
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																				
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
S	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																								
S	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																								
S	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																								
S	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																				
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																				V																																				
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																								
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																				V																																				
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
S	2015	Aveo	Powertrain	Chassis Control Module																																																								
S	2015	Aveo	Powertrain	Fuel Injector Control Module																																																								
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2015	Aveo	Chassis	Power Steering Control Module																																																								
S	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
S	2015	Aveo	Body	Body Control Module Hatchback						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V						
S	2015	Aveo	Body	Body Control Module Sedan						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V						
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																													
S	2015	Aveo	Body	Instrument Cluster																																V																						
S	2015	Aveo	Body	Radio																																																						
S	2015	Aveo	Body	Telematics Communication Interface Control Module																																	V	V	V																			
S	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																											V										
S	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V										
S	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																											V										
S	2015	Aveo	Body	Front Seat Heating Control Module																																					V	V																
S	2015	Aveo	Body	Keyless Entry Control Module																																																							
S	2015	Aveo	Body	Parking Assist Control Module																																																							
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																							
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																							
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																							
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																							
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																							
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																							
S	2015	Sail	Powertrain	Transmission Control Module																																																							
S	2015	Sail	Chassis	Electronic Brake Control Module																																																							
S	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																													
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																				
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																							
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																				V																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
S	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																								
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																								
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																								
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
S	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
S	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																								
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																				V																																								
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																				V																																								
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
S	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
S	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
S	2016	Aveo	Powertrain	Chassis Control Module																																																												
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2016	Aveo	Chassis	Power Steering Control Module																																																												
S	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																						
S	2016	Aveo	Body	Body Control Module Hatchback						V	V	V		V	V			V	V		V	V	V	V	V		V	V																								V									
S	2016	Aveo	Body	Body Control Module Sedan						V	V	V		V	V			V	V		V	V	V	V	V		V	V																								V									
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																		
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
S	2016	Aveo	Body	Instrument Cluster																																V																											
S	2016	Aveo	Body	Radio																																																										
S	2016	Aveo	Body	Telematics Communication Interface Control Module																																	V	V	V																					
S	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V													
S	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																											V													
S	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																											V													
S	2016	Aveo	Body	Front Seat Heating Control Module																																					V	V																			
S	2016	Aveo	Body	Parking Assist Control Module																																V																									
S	2016	Aveo	Body	Keyless Entry Control Module																																																											
S	2016	Aveo	Body	Frontview Camera Module																																																											
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																										
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
S	2016	Sail	Powertrain	Transmission Control Module																																																											
S	2016	Sail	Chassis	Electronic Brake Control Module																																																											
S	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																		
T	2004	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																											
T	2004	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
T	2004	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																											
T	2004	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
T	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
T	2004	ALL	Powertrain	Transmission Control Module																																																											
T	2004	ALL	Chassis	Electronic Brake Control Module																																																											
T	2004	ALL	Chassis	Electronic Brake Control Module																																																											
T	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2004	ALL	Body	Remote Function Actuation																														V																												
T	2005	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																											
T	2005	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
T	2005	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																											
T	2005	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
T	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
T	2005	ALL	Powertrain	Transmission Control Module																																																											
T	2005	ALL	Chassis	Electronic Brake Control Module																																																											
T	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2005	ALL	Body	Remote Function Actuation																														V																												
T	2006	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																											
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																											
T	2006	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																											
T	2006	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																											
T	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
T	2006	ALL	Chassis	Electronic Brake Control Module																																																											
T	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2006	ALL	Body	Remote Function Actuation																														V																												
T	2007	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																											
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																											
T	2007	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																											
T	2007	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																											
T	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																											
T	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
T	2007	ALL	Chassis	Electronic Brake Control Module																																																											
T	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2007	ALL	Body	Remote Function Actuation																														V																												
T	2008	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																											
T	2008	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																											
T	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2008	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
T	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
T	2008	ALL	Powertrain	Transmission Control Module																																																										
T	2008	ALL	Powertrain	Transmission Control Module																																																										
T	2008	ALL	Chassis	Electronic Brake Control Module																																																										
T	2008	ALL	Chassis	Tire Pressure Monitor																																																										
T	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2008	ALL	Body	Remote Function Actuation																														V																												
T	2008	ALL	Body	Passenger Presence System																																																									
T	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
T	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
T	2009	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
T	2009	ALL	Powertrain	Transmission Control Module																																																										
T	2009	ALL	Powertrain	Transmission Control Module																																																										
T	2009	ALL	Chassis	Electronic Brake Control Module																																																										
T	2009	ALL	Chassis	Tire Pressure Monitor																																																										
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2009	ALL	Body	Instrument Panel Cluster																																																										
T	2009	ALL	Body	Passenger Presence System																																																										
T	2009	ALL	Body	Theft Deterrent Module																																																										
T	2009	ALL	Body	Radio																																																										
T	2009	ALL	Body	Remote Function Actuation																														V																												
T	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
T	2010	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2010	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
T	2010	ALL	Powertrain	Transmission Control Module																																																										
T	2010	ALL	Powertrain	Transmission Control Module																																																										
T	2010	ALL	Chassis	Electronic Brake Control Module																																																										
T	2010	ALL	Chassis	Tire Pressure Monitor																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Instrument Panel Cluster																																																										
T	2010	ALL	Body	Passenger Presence System																																																										
T	2010	ALL	Body	Theft Deterrent Module																																																										
T	2010	ALL	Body	Radio																																																										
T	2010	ALL	Body	Remote Function Actuation																														V																												
T	2011	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
T	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2011	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2011	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module Argentia																																																										
T	2011	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
T	2011	ALL	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																										
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2011	ALL	Chassis	Electronic Brake Control Module																																																										
T	2011	ALL	Chassis	Tire Pressure Monitor																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2011	ALL	Body	Instrument Panel Cluster																																																								
T	2011	ALL	Body	Passenger Presence System																																																								
T	2011	ALL	Body	Theft Deterrent Module																																																								
T	2011	ALL	Body	Radio																																																								
T	2011	ALL	Body	Remote Function Actuation																														V																									
T	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																								
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																				
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
T	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
T	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																								
T	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
T	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																				
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																				V																																				
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																								
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																				V																																				
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
T	2012	Aveo	Powertrain	Fuel Injector Control Module																																																								
T	2012	Aveo	Powertrain	Fuel Pump Control Module																																																								
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2012	Aveo	Chassis	Electric Power Steering Control Module																																																								
T	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
T	2012	Aveo	Chassis	Tire Pressure Monitor																																																								
T	2012	Aveo	Body	Body Control Module Hatchback						V	V	V	V	V	V		V	V		V	V	V	V		V	V																									V							
T	2012	Aveo	Body	Body Control Module Sedan						V	V	V	V	V	V		V	V		V	V	V	V		V	V																									V							
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	Aveo	Body	Passenger Presence Module																															V																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2012	Aveo	Body	Instrument Cluster																																	V																								
T	2012	Aveo	Body	Radio																																																								
T	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																								
T	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																												V											
T	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V											
T	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																												V											
T	2012	Aveo	Body	Front Seat Heating Control Module																																					V	V																		
T	2012	Aveo	Body	Remote Function Actuation																														V																									
T	2012	Aveo	Body	Parking Assist Control Module																																																							
T	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																							
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																			
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																							
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																				V																																			
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																							
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																							
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																							
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																							
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																							
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																			
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																							
T	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																							
T	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																							
T	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																							
T	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																							
T	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																							
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																			
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																							
T	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																							
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																				V																																			
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																							
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																							
T	2013	Aveo	Powertrain	Fuel Injector Control Module																																																							
T	2013	Aveo	Powertrain	Fuel Pump Control Module																																																							
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																							
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																							
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																							
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																							
T	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																							
T	2013	Aveo	Chassis	Electric Power Steering Control Module																																																							
T	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
T	2013	Aveo	Body	Body Control Module Hatchback						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V						
T	2013	Aveo	Body	Body Control Module Sedan						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V						
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
T	2013	Aveo	Body	Passenger Presence Module																																V																							
T	2013	Aveo	Body	Instrument Cluster																																	V																							
T	2013	Aveo	Body	Radio																																																							
T	2013	Aveo	Body	Telematics Communication Interface Control Module																																		V	V	V	V																		
T	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																												V											
T	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V											
T	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																												V											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2013	Aveo	Body	Front Seat Heating Control Module																																						V	V																			
T	2013	Aveo	Body	Remote Function Actuation																															V																												
T	2013	Aveo	Body	Parking Assist Control Module																																																										
T	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																						
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																				V																																						
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
T	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																				V																																						
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																						
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
T	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
T	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
T	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																						
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																				V																																						
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																				V																																						
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
T	2014	Aveo	Powertrain	Chassis Control Module																																																										
T	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	Aveo	Chassis	Power Steering Control Module																																																										
T	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
T	2014	Aveo	Body	Body Control Module Hatchback						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																								V								
T	2014	Aveo	Body	Body Control Module Sedan						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																								V								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																															
T	2014	Aveo	Body	Instrument Cluster																																V																								
T	2014	Aveo	Body	Radio																																																							
T	2014	Aveo	Body	Telematics Communication Interface Control Module																																	V	V	V	V																				
T	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																											V											
T	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V											
T	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																											V											
T	2014	Aveo	Body	Front Seat Heating Control Module																																					V	V																		
T	2014	Aveo	Body	Keyless Entry Control Module																																																							
T	2014	Aveo	Body	Parking Assist Control Module																																																							
T	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																							
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																				
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																				V																																				
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																							
T	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																							
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																							
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																				V																																				
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																							
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																				
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																							
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																							
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																				
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																							
T	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																							
T	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																							
T	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																							
T	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																							
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																				
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																							
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																				V																																				
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																							
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																				V																																				
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																							
T	2015	Aveo	Powertrain	Chassis Control Module																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2015	Aveo	Powertrain	Fuel Injector Control Module																																																								
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2015	Aveo	Chassis	Power Steering Control Module																																																								
T	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
T	2015	Aveo	Body	Body Control Module Hatchback						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V						
T	2015	Aveo	Body	Body Control Module Sedan						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V						
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																															
T	2015	Aveo	Body	Instrument Cluster																																V																								
T	2015	Aveo	Body	Radio																																																								
T	2015	Aveo	Body	Telematics Communication Interface Control Module																																	V	V	V																					
T	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																												V												
T	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V												
T	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																												V												
T	2015	Aveo	Body	Front Seat Heating Control Module																																					V	V																		
T	2015	Aveo	Body	Keyless Entry Control Module																																																								
T	2015	Aveo	Body	Parking Assist Control Module																																																								
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																				V																																				
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																				V																																				
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
T	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																								
T	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																								
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																				
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
T	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
T	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																								
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																				
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
T	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
T	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																								
T	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																								
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																				V																																				
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
T	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																				V																																				
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																								
T	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																								
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																				V																																				
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																								
T	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																								
T	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																								
T	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
T	2016	Aveo	Powertrain	Chassis Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2016	Aveo	Chassis	Power Steering Control Module																																																								
T	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
T	2016	Aveo	Body	Body Control Module Hatchback						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V							
T	2016	Aveo	Body	Body Control Module Sedan						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V							
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																										V																														
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																								
T	2016	Aveo	Body	Instrument Cluster																																V																								
T	2016	Aveo	Body	Radio																																																								
T	2016	Aveo	Body	Telematics Communication Interface Control Module																																	V	V	V																					
T	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V													
T	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																											V													
T	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																											V													
T	2016	Aveo	Body	Front Seat Heating Control Module																																					V	V																		
T	2016	Aveo	Body	Parking Assist Control Module																																V																								
T	2016	Aveo	Body	Keyless Entry Control Module																																																								
T	2016	Aveo	Body	Frontview Camera Module																																																								
U	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
U	2004	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																								
U	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
U	2004	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																								
U	2004	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
U	2004	ALL	Chassis	Electronic Brake Control Module																																																								
U	2004	ALL	Chassis	Electronic Brake Control Module																																																								
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2004	ALL	Body	Remote Function Actuation																															V																									
U	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
U	2005	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																								
U	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
U	2005	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																								
U	2005	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
U	2005	ALL	Chassis	Electronic Brake Control Module																																																								
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2005	ALL	Body	Remote Function Actuation																															V																									
U	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
U	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
U	2006	ALL	Powertrain	Transmission Control Module																																																								
U	2006	ALL	Chassis	Electronic Brake Control Module																																																								
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2006	ALL	Body	Remote Function Actuation																															V																									
U	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
U	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
U	2007	ALL	Powertrain	Transmission Control Module																																																								
U	2007	ALL	Chassis	Electronic Brake Control Module																																																								
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
U	2007	ALL	Body	Remote Function Actuation																															V																											
U	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
U	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
U	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
U	2008	ALL	Powertrain	Transmission Control Module																																																										
U	2008	ALL	Chassis	Electronic Brake Control Module																																																										
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2008	ALL	Body	Remote Function Actuation																															V																											
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
U	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
U	2010	Sail	Powertrain	Transmission Control Module																																																										
U	2010	Sail	Chassis	Electronic Brake Control Module																																																										
U	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																	
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
U	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
U	2011	Sail	Powertrain	Transmission Control Module																																																										
U	2011	Sail	Chassis	Electronic Brake Control Module																																																										
U	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																	
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																										
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																										
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
U	2012	Sail	Powertrain	Transmission Control Module																																																										
U	2012	Sail	Chassis	Electronic Brake Control Module																																																										
U	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																	
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
U	2013	Sail	Powertrain	Transmission Control Module																																																										
U	2013	Sail	Chassis	Electronic Brake Control Module																																																										
U	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																	
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
U	2014	Sail	Powertrain	Transmission Control Module																																																										
U	2014	Sail	Chassis	Electronic Brake Control Module																																																										
U	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																	
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																									
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
U	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																					V					
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
U	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																				V					
U	2015	Sail	Powertrain	Transmission Control Module																																																										
U	2015	Sail	Chassis	Electronic Brake Control Module																																																										
U	2015	Sail	Chassis	Electronic Brake Control Module																																																										
U	2015	Sail	Chassis	Power Steering Control Module	V		V																																																							
U	2015	Sail	Body	Body Control Module						V		V		V					V		V		V																																							
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
U	2015	Sail	Body	Radio/HVAC Control																																																										
U	2015	Sail	Body	HVAC Control Module																															V												V	V	V	V	V									
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
U	2016	Sail	Powertrain	1.2L LMU Transmission Control Module																																																										
U	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																										
U	2016	Sail	Powertrain	1.3L LDV Transmission Control Module																																																										
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
U	2016	Sail	Powertrain	1.4L LCU Transmission Control Module																																																										
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																				V					
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																				V					
U	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																										
U	2016	Sail	Chassis	Electronic Brake Control Module																																																										
U	2016	Sail	Chassis	Electronic Brake Control Module																																																										
U	2016	Sail	Chassis	Power Steering Control Module	V		V																																																							
U	2016	Sail	Body	Body Control Module						V		V		V					V		V		V																																							
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V																																
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
U	2016	Sail	Body	Radio/HVAC Control																																																										
U	2016	Sail	Body	Radio																																																										
U	2016	Sail	Body	HVAC Control Module																															V												V	V	V	V	V									
V	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
V	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2004	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																										
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																										
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2004	ALL	Body	ISU																																																										
V	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
V	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2005	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
V	2005	ALL	Chassis	Electronic Brake Control Module																																																										
V	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2005	ALL	Body	ISU																																																										
V	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
V	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
V	2006	ALL	Powertrain	Transmission Control Module 4 Speed																																																									
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																									
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																									
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2006	ALL	Body	ISU																																																									
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																									
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector Control Module																																																									
V	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																									
V	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																									
V	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
V	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
V	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																									
V	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																									
V	2007	ALL	Chassis	Electronic Brake Control Module																																																									
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2007	ALL	Body	ISU																																																									
V	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
V	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
V	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																									
V	2008	ALL	Chassis	Electronic Brake Control Module																																																									
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2008	ALL	Body	ISU																																																									
V	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
V	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
V	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																									
V	2009	ALL	Chassis	Electronic Brake Control Module																																																									
V	2009	ALL	Body	ISU																																																									
V	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																									
V	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
V	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
V	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																									
V	2010	ALL	Chassis	Electronic Brake Control Module																																																									
V	2010	ALL	Body	ISU																																																									
V	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																									
V	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
V	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
V	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																									
V	2011	ALL	Chassis	Electronic Brake Control Module																																																									
V	2011	ALL	Body	ISU																																																									
W	2004	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																									
W	2004	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																									
W	2004	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																									
W	2004	ALL	Powertrain	Transmission Control Module																																																									
W	2004	ALL	Body	Body Control Module																														V																											
W	2004	ALL	Body	Digital Radio Receiver																																																									
W	2004	ALL	Body	Driver Information Center																																																									
W	2004	ALL	Body	Heating and Air Conditioning																																																									
W	2004	ALL	Body	Instrument Panel Cluster																																																									
W	2004	ALL	Body	Personalization																																																									
W	2004	ALL	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
W	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																								
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																								
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																								
W	2005	ALL	Powertrain	Transmission Control Module																																																								
W	2005	ALL	Body	Body Control Module																														V																										
W	2005	ALL	Body	Digital Radio Receiver																																																							
W	2005	ALL	Body	Driver Information Center																																																							
W	2005	ALL	Body	Heating and Air Conditioning																																																							
W	2005	ALL	Body	Instrument Panel Cluster																																																							
W	2005	ALL	Body	Personalization																																																							
W	2005	ALL	Body	Radio																																																							
W	2005	ALL	Body	Supplemental Inflatable Restraint																																																							
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																							
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																							
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																							
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																							
W	2006	ALL	Powertrain	Transmission Control Module																																																							
W	2006	ALL	Chassis	Anti-lock Brake System																																																							
W	2006	ALL	Body	Digital Radio Receiver																																																							
W	2006	ALL	Body	Radio																																																							
W	2006	ALL	Body	Instrument Panel Cluster																																																							
W	2006	ALL	Body	Seat																																																							
W	2006	ALL	Body	Theft Deterrent Module																																																							
W	2006	ALL	Body	Body Control Module																																																							
W	2006	ALL	Body	HVAC C67 Single																																											V												
W	2006	ALL	Body	HVAC CJ3 Dual																																											V												
W	2006	ALL	Body	Remote Control Door Lock Receiver																																																							
W	2006	ALL	Body	Supplemental Inflatable Restraint																																																							
W	2006	ALL	Body	Passenger Presence System																																																							
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																							
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																							
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																							
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module																																																							
W	2007	ALL	Powertrain	Transmission Control Module																																																							
W	2007	ALL	Chassis	Electronic Brake Control Module																																																							
W	2007	ALL	Body	Body Control Module																																																							
W	2007	ALL	Body	Digital Radio Receiver																																																							
W	2007	ALL	Body	Heated Seat Module																																																							
W	2007	ALL	Body	HVAC C67 Single																																											V												
W	2007	ALL	Body	HVAC CJ3 Dual																																											V												
W	2007	ALL	Body	Instrument Panel Cluster																																																							
W	2007	ALL	Body	Passenger Presence System																																																							
W	2007	ALL	Body	Radio																																																							
W	2007	ALL	Body	Supplemental Inflatable Restraint																																																							
W	2007	ALL	Body	Theft Deterrent Module																																																							
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																							
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																							
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module																																																							
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																							
W	2008	ALL	Powertrain	Transmission Control Module																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
W	2008	ALL	Chassis	Electronic Brake Control Module																																																										
W	2008	ALL	Body	Body Control Module																																																										
W	2008	ALL	Body	Digital Radio Receiver																																																										
W	2008	ALL	Body	Heated Seat Module																																																										
W	2008	ALL	Body	HVAC C67 Single																																											V															
W	2008	ALL	Body	HVAC CJ3 Dual																																											V															
W	2008	ALL	Body	Instrument Panel Cluster																																																										
W	2008	ALL	Body	Passenger Presence System																																																										
W	2008	ALL	Body	Radio																																																										
W	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2008	ALL	Body	Theft Deterrent Module																																																										
W	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
W	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
W	2009	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																										
W	2009	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																										
W	2009	ALL	Powertrain	Transmission Control Module																																																										
W	2009	ALL	Chassis	Electronic Brake Control Module																																																										
W	2009	ALL	Body	Body Control Module																																																										
W	2009	ALL	Body	Digital Radio Receiver																																																										
W	2009	ALL	Body	Heated Seat Module																																																										
W	2009	ALL	Body	HVAC C67 Single																																											V															
W	2009	ALL	Body	HVAC CJ3 Dual																																											V															
W	2009	ALL	Body	Instrument Panel Cluster																																																										
W	2009	ALL	Body	Passenger Presence System																																																										
W	2009	ALL	Body	Radio																																																										
W	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2009	ALL	Body	Theft Deterrent Module																																																										
W	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
W	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
W	2010	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																										
W	2010	ALL	Powertrain	Transmission Control Module																																																										
W	2010	ALL	Chassis	Electronic Brake Control Module																																																										
W	2010	ALL	Body	Body Control Module																																																										
W	2010	ALL	Body	Digital Radio Receiver																																																										
W	2010	ALL	Body	Heated Seat Module																																																										
W	2010	ALL	Body	HVAC C67 Single																																											V															
W	2010	ALL	Body	HVAC CJ3 Dual																																											V															
W	2010	ALL	Body	Instrument Panel Cluster																																																										
W	2010	ALL	Body	Passenger Presence System																																																										
W	2010	ALL	Body	Radio																																																										
W	2010	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2010	ALL	Body	Theft Deterrent Module																																																										
W	2011	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
W	2011	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																										
W	2011	ALL	Powertrain	Transmission Control Module																																																										
W	2011	ALL	Chassis	Electronic Brake Control Module																																																										
W	2011	ALL	Body	Body Control Module																																																										
W	2011	ALL	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
W	2011	ALL	Body	Heated Seat Module																																																									
W	2011	ALL	Body	HVAC C67 Single																																												V												
W	2011	ALL	Body	HVAC CJ3 Dual																																												V												
W	2011	ALL	Body	Instrument Panel Cluster																																																								
W	2011	ALL	Body	Passenger Presence System																																																								
W	2011	ALL	Body	Radio																																																								
W	2011	ALL	Body	Remote Control Door Lock Receiver																																																								
W	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
W	2011	ALL	Body	Theft Deterrent Module																																																								
W	2012	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																								
W	2012	ALL	Powertrain	Transmission Control Module																																																								
W	2012	ALL	Powertrain	Fuel Pump Control Module																																																								
W	2012	ALL	Chassis	Electronic Brake Control Module																																																								
W	2012	ALL	Body	Body Control Module																																																								
W	2012	ALL	Body	Digital Radio Receiver																																																								
W	2012	ALL	Body	Heated Seat Module																																																								
W	2012	ALL	Body	HVAC C67 Single																																												V												
W	2012	ALL	Body	HVAC CJ3 Dual																																												V												
W	2012	ALL	Body	Instrument Panel Cluster																																																								
W	2012	ALL	Body	Passenger Presence System																																																								
W	2012	ALL	Body	Radio																																																								
W	2012	ALL	Body	Remote Control Door Lock Receiver																																																								
W	2012	ALL	Body	Supplemental Inflatable Restraint																									V	V																															
W	2012	ALL	Body	Theft Deterrent Module																																																								
W	2013	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																				V																																					
W	2013	ALL	Powertrain	Transmission Control Module																																																								
W	2013	ALL	Powertrain	Fuel Pump Control Module																																																								
W	2013	ALL	Chassis	Electronic Brake Control Module																																																								
W	2013	ALL	Body	Body Control Module																																																								
W	2013	ALL	Body	Digital Radio Receiver																																																								
W	2013	ALL	Body	Heated Seat Module																																																								
W	2013	ALL	Body	HVAC C67 Single																																												V												
W	2013	ALL	Body	HVAC CJ3 Dual																																												V												
W	2013	ALL	Body	Instrument Panel Cluster																																																								
W	2013	ALL	Body	Passenger Presence System																																																								
W	2013	ALL	Body	Radio																																																								
W	2013	ALL	Body	Remote Control Door Lock Receiver																																																								
W	2013	ALL	Body	Supplemental Inflatable Restraint																									V	V																															
W	2013	ALL	Body	Theft Deterrent Module																																																								
W	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																					
W	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
W	2014	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																								
W	2014	Impala	Chassis	Electronic Brake Control Module					V																																																			
W	2014	Impala	Body	Body Control Module						V	V	V						V				V	V	V																																				
W	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
W	2014	Impala	Body	Passenger Presence Module																										V						V																								
W	2014	Impala	Body	Instrument Cluster																																																								
W	2014	Impala	Body	Radio																																																								
W	2014	Impala	Body	Digital Radio Receiver Control Module																																																								
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																			
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
W	2014	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																											V	V		V	V								
W	2014	Impala	Body	HVAC Manual Control Single Zone (C67)																																											V	V		V	V								
W	2014	Impala	Body	Front Seat Heating Control Module																																					V	V																	
W	2014	Impala	Body	Remote Control Door Lock Receiver																																																							
W	2014	Impala	Body	Theft Deterrent Module										V																																													
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																				V																																			
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																							
W	2014	Lumina	Powertrain	(2) 6.0L L77 Transmission Control Module																																																						
W	2014	Lumina	Powertrain	Fuel Injector Control Module																																																						
W	2014	Lumina	Powertrain	Chassis Control Module																																																						
W	2014	Lumina	Chassis	Electronic Brake Control Module					V																																																	
W	2014	Lumina	Chassis	Parking Brake Control Module																																																						
W	2014	Lumina	Chassis	Power Steering Control Module	V																																																					
W	2014	Lumina	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
W	2014	Lumina	Chassis	Suspension Control Module																																																					
W	2014	Lumina	Body	Body Control Module Coupe						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																														
W	2014	Lumina	Body	Body Control Module Sedan						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																														
W	2014	Lumina	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
W	2014	Lumina	Body	Instrument Cluster																																V																						
W	2014	Lumina	Body	Head-Up Display Module																																																					
W	2014	Lumina	Body	Radio Control																																V																					
W	2014	Lumina	Body	HVAC Control																																																					
W	2014	Lumina	Body	Headlamp Control Module																																																					
W	2014	Lumina	Body	Trailer Interface Control Module																																																					
W	2014	Lumina	Body	Radio																																																					
W	2014	Lumina	Body	HVAC Control Module																														V													V	V	V		V							
W	2014	Lumina	Body	Keyless Entry Control Module																																																					
W	2014	Lumina	Body	Right Side Object Detection Control Module																																																					
W	2014	Lumina	Body	Left Side Object Detection Control Module																																																					
W	2014	Lumina	Body	Parking Assist Control Module																																V																					
W	2014	Lumina	Body	Frontview Camera Module																																																					
W	2014	Lumina	Body	Steering Column Lock Control Module																																																					
W	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																		
W	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																					
W	2015	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																					
W	2015	Impala	Chassis	Electronic Brake Control Module					V																																																
W	2015	Impala	Body	Body Control Module						V	V	V						V				V	V	V																																	
W	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																							
W	2015	Impala	Body	Passenger Presence Module																										V					V																						
W	2015	Impala	Body	Instrument Cluster																																																				
W	2015	Impala	Body	Radio																																																				
W	2015	Impala	Body	Digital Radio Receiver Control Module																																																				
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																
W	2015	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																											V	V		V	V							
W	2015	Impala	Body	HVAC Manual Control Single Zone (C67)																																											V	V		V	V							
W	2015	Impala	Body	Front Seat Heating Control Module																																					V	V															
W	2015	Impala	Body	Remote Control Door Lock Receiver																																																				
W	2015	Impala	Body	Theft Deterrent Module										V																																											
W	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																	
W	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
W	2016	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																									
W	2016	Impala	Chassis	Electronic Brake Control Module					V																																																					
W	2016	Impala	Body	Body Control Module						V	V	V						V				V	V	V																																					
W	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																												
W	2016	Impala	Body	Passenger Presence Module																										V						V																											
W	2016	Impala	Body	Instrument Cluster																																																									
W	2016	Impala	Body	Radio																																																									
W	2016	Impala	Body	Digital Radio Receiver Control Module																																																									
W	2016	Impala	Body	Telematics Communication Interface Control Module																																	V	V	V																							
W	2016	Impala	Body	HVAC Manual Control Dual Zone (CJ2)																																											V	V		V	V								
W	2016	Impala	Body	HVAC Manual Control Single Zone (C67)																																											V	V		V	V								
W	2016	Impala	Body	Front Seat Heating Control Module																																					V	V																			
W	2016	Impala	Body	Remote Control Door Lock Receiver																																																									
W	2016	Impala	Body	Theft Deterrent Module										V																																															
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Auto																																																									
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Manual																																																									
Y	2004	ALL	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																									
Y	2004	ALL	Powertrain	Transmission Control Module																																																									
Y	2004	ALL	Chassis	RTD																														V																											
Y	2004	ALL	Body	Body Control Module																																																								
Y	2004	ALL	Body	Heating and Air Conditioning																																																									
Y	2004	ALL	Body	Instrument Panel Cluster																																																									
Y	2004	ALL	Body	Left Door Control Module																																																									
Y	2004	ALL	Body	Radio																																																									
Y	2004	ALL	Body	Remote Function Actuation																																																									
Y	2004	ALL	Body	Right Door Control Module																																																									
Y	2004	ALL	Body	Seat Control Module																																																									
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2005	ALL	Powertrain	Engine Control Module																																																									
Y	2005	ALL	Powertrain	Transmission Control Module																																																									
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																									
Y	2005	ALL	Chassis	Electronic Suspension Control																																																									
Y	2005	ALL	Chassis	Steering Wheel and Column																																																									
Y	2005	ALL	Body	Amplifier																																																									
Y	2005	ALL	Body	Body Control Module																																																									
Y	2005	ALL	Body	Digital Radio Receiver																																																									
Y	2005	ALL	Body	Driver Door Module																																																									
Y	2005	ALL	Body	Driver Door Switch																																																									
Y	2005	ALL	Body	Driver Position Module																																																									
Y	2005	ALL	Body	Folding Top Module																																																									
Y	2005	ALL	Body	Head Up Display																																																									
Y	2005	ALL	Body	HVAC Control Module																																												V														
Y	2005	ALL	Body	Instrument Panel Cluster																																																									
Y	2005	ALL	Body	Navigation Radio																																																									
Y	2005	ALL	Body	Passenger Door Module																																																									
Y	2005	ALL	Body	Radio																																																									
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																									
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2006	ALL	Powertrain	Engine Control Module																																																									
Y	2006	ALL	Powertrain	Exhaust Flow Control Module																																																									
Y	2006	ALL	Powertrain	Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Y	2006	ALL	Chassis	Electronic Brake Control Module																																																									
Y	2006	ALL	Chassis	Electronic Suspension Control																																																										
Y	2006	ALL	Chassis	Steering Wheel and Column																																																										
Y	2006	ALL	Body	Body Control Module																																																										
Y	2006	ALL	Body	CD Changer																																																										
Y	2006	ALL	Body	Digital Radio Receiver																																																										
Y	2006	ALL	Body	Driver Door Module																																																										
Y	2006	ALL	Body	Driver Door Switch																																																										
Y	2006	ALL	Body	Driver Position Module																																																										
Y	2006	ALL	Body	Folding Top Module																																																										
Y	2006	ALL	Body	Head Up Display																																																										
Y	2006	ALL	Body	HVAC Control Module																																												V														
Y	2006	ALL	Body	Instrument Panel Cluster																																																										
Y	2006	ALL	Body	Navigation Radio																																																										
Y	2006	ALL	Body	Passenger Door Module																																																										
Y	2006	ALL	Body	Radio																																																										
Y	2006	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2007	ALL	Powertrain	Engine Control Module																																																										
Y	2007	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	ALL	Powertrain	Transmission Control Module																																																										
Y	2007	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2007	ALL	Chassis	Electronic Suspension Control																																																										
Y	2007	ALL	Body	Body Control Module																																																										
Y	2007	ALL	Body	CD Changer																																																										
Y	2007	ALL	Body	Digital Radio Receiver																																																										
Y	2007	ALL	Body	Driver Door Module																																																										
Y	2007	ALL	Body	Driver Door Switch																																																										
Y	2007	ALL	Body	Driver Position Module																																																										
Y	2007	ALL	Body	Folding Top Module																																																										
Y	2007	ALL	Body	Head Up Display																																																										
Y	2007	ALL	Body	HVAC Control Module																																										V														
Y	2007	ALL	Body	Instrument Panel Cluster																																																										
Y	2007	ALL	Body	Navigation Radio																																																										
Y	2007	ALL	Body	Passenger Door Module																																																										
Y	2007	ALL	Body	Radio																																																										
Y	2007	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2007	ALL	Body	Steering Column Lock Module																																																										
Y	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Powertrain	Engine Control Module																																																										
Y	2008	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2008	ALL	Powertrain	Transmission Control Module																																																										
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2008	ALL	Chassis	Electronic Suspension Control																																																										
Y	2008	ALL	Body	Body Control Module																																																										
Y	2008	ALL	Body	CD Changer																																																										
Y	2008	ALL	Body	Digital Radio Receiver																																																										
Y	2008	ALL	Body	Driver Door Module																																																										
Y	2008	ALL	Body	Driver Door Switch																																																										
Y	2008	ALL	Body	Driver Position Module																																																										
Y	2008	ALL	Body	Folding Top Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Y	2008	ALL	Body	Head Up Display																																																									
Y	2008	ALL	Body	HVAC Control Module																																												V												
Y	2008	ALL	Body	Instrument Panel Cluster																																																								
Y	2008	ALL	Body	Navigation Radio																																																								
Y	2008	ALL	Body	Passenger Door Module																																																								
Y	2008	ALL	Body	Radio																																																								
Y	2008	ALL	Body	Personal Audio Link Module																																																								
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2008	ALL	Body	Steering Column Lock Module																																																								
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																								
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																								
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																								
Y	2009	ALL	Chassis	Electronic Brake Control Module																																																								
Y	2009	ALL	Chassis	Electronic Suspension Control																																																								
Y	2009	ALL	Body	Body Control Module																																																								
Y	2009	ALL	Body	CD Changer																																																								
Y	2009	ALL	Body	Digital Radio Receiver																																																								
Y	2009	ALL	Body	Driver Door Module																																																								
Y	2009	ALL	Body	Driver Door Switch																																																								
Y	2009	ALL	Body	Driver Position Module																																																								
Y	2009	ALL	Body	Folding Top Module																																																								
Y	2009	ALL	Body	Head Up Display																																																								
Y	2009	ALL	Body	HVAC Control Module																																										V												
Y	2009	ALL	Body	Instrument Panel Cluster																																																								
Y	2009	ALL	Body	Navigation Radio																																																								
Y	2009	ALL	Body	Passenger Door Module																																																								
Y	2009	ALL	Body	Radio																																																								
Y	2009	ALL	Body	Personal Audio Link Module																																																								
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2009	ALL	Body	Steering Column Lock Module																																																								
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																								
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																								
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																								
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																								
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																								
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																								
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																								
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																								
Y	2010	ALL	Chassis	Electronic Brake Control Module																																																								
Y	2010	ALL	Chassis	Electronic Suspension Control																																																								
Y	2010	ALL	Body	Body Control Module																																																								
Y	2010	ALL	Body	CD Changer																																																								
Y	2010	ALL	Body	Digital Radio Receiver																																																								
Y	2010	ALL	Body	Driver Door Module																																																								
Y	2010	ALL	Body	Driver Door Switch																																																								
Y	2010	ALL	Body	Driver Position Module																																																								
Y	2010	ALL	Body	Folding Top Module																																																								
Y	2010	ALL	Body	Head Up Display																																																								
Y	2010	ALL	Body	HVAC Control Module																																										V												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Y	2010	ALL	Body	Instrument Panel Cluster																																																											
Y	2010	ALL	Body	Navigation Radio																																																											
Y	2010	ALL	Body	Passenger Door Module																																																											
Y	2010	ALL	Body	Radio																																																											
Y	2010	ALL	Body	Personal Audio Link Module																																																											
Y	2010	ALL	Body	Remote Control Door Lock Receiver																																																											
Y	2010	ALL	Body	Steering Column Lock Module																																																											
Y	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																											
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																											
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																											
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																											
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																											
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																											
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																											
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																											
Y	2011	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2011	ALL	Chassis	Electronic Suspension Control																																																												
Y	2011	ALL	Body	Body Control Module																																																											
Y	2011	ALL	Body	CD Changer																																																											
Y	2011	ALL	Body	Digital Radio Receiver																																																											
Y	2011	ALL	Body	Driver Door Module																																																											
Y	2011	ALL	Body	Driver Door Switch																																																											
Y	2011	ALL	Body	Driver Position Module																																																											
Y	2011	ALL	Body	Folding Top Module																																																											
Y	2011	ALL	Body	Head Up Display																																																											
Y	2011	ALL	Body	HVAC Control Module																																												V															
Y	2011	ALL	Body	Instrument Panel Cluster																																																											
Y	2011	ALL	Body	Navigation Radio																																																											
Y	2011	ALL	Body	Passenger Door Module																																																											
Y	2011	ALL	Body	Radio																																																											
Y	2011	ALL	Body	Personal Audio Link Module																																																											
Y	2011	ALL	Body	Remote Control Door Lock Receiver																																																											
Y	2011	ALL	Body	Steering Column Lock Module																																																											
Y	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																											
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																											
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																											
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																											
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																											
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																											
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																											
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																											
Y	2012	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2012	ALL	Chassis	Electronic Suspension Control																																																											
Y	2012	ALL	Body	Body Control Module																																																										
Y	2012	ALL	Body	CD Changer																																																										
Y	2012	ALL	Body	Digital Radio Receiver																																																										
Y	2012	ALL	Body	Driver Door Module																																																										
Y	2012	ALL	Body	Driver Door Switch																																																										
Y	2012	ALL	Body	Driver Position Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Y	2012	ALL	Body	Folding Top Module																																																									
Y	2012	ALL	Body	Head Up Display																																																									
Y	2012	ALL	Body	HVAC Control Module																																												V												
Y	2012	ALL	Body	Instrument Panel Cluster																																																								
Y	2012	ALL	Body	Navigation Radio																																																								
Y	2012	ALL	Body	Passenger Door Module																																																								
Y	2012	ALL	Body	Radio																																																								
Y	2012	ALL	Body	Personal Audio Link Module																																																								
Y	2012	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2012	ALL	Body	Steering Column Lock Module																																																								
Y	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																								
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																								
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																								
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																								
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																								
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																								
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																								
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																								
Y	2013	ALL	Chassis	Electronic Brake Control Module																																																								
Y	2013	ALL	Chassis	Electronic Suspension Control																																																								
Y	2013	ALL	Body	Body Control Module																																																								
Y	2013	ALL	Body	CD Changer																																																								
Y	2013	ALL	Body	Digital Radio Receiver																																																								
Y	2013	ALL	Body	Driver Door Module																																																								
Y	2013	ALL	Body	Driver Door Switch																																																								
Y	2013	ALL	Body	Driver Position Module																																																								
Y	2013	ALL	Body	Folding Top Module																																																								
Y	2013	ALL	Body	Head Up Display																																																								
Y	2013	ALL	Body	HVAC Control Module																																												V												
Y	2013	ALL	Body	Instrument Panel Cluster																																																								
Y	2013	ALL	Body	Navigation Radio																																																								
Y	2013	ALL	Body	Passenger Door Module																																																								
Y	2013	ALL	Body	Radio																																																								
Y	2013	ALL	Body	Personal Audio Link Module																																																								
Y	2013	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2013	ALL	Body	Steering Column Lock Module																																																								
Y	2013	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																				V																																				
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																				V																																				
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																								
Y	2014	Corvette	Powertrain	Chassis Control Module																																																								
Y	2014	Corvette	Chassis	Electronic Brake Control Module					V																																																			
Y	2014	Corvette	Chassis	Parking Brake Control Module																																																								
Y	2014	Corvette	Chassis	Power Steering Control Module	V	V	V																																																					
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
Y	2014	Corvette	Chassis	Suspension Control Module																																																								
Y	2014	Corvette	Body	Body Control Module Convertible						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																								V						
Y	2014	Corvette	Body	Body Control Module Coupe						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																								V						
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
Y	2014	Corvette	Body	Passenger Presence Module																				V																																			

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Y	2014	Corvette	Body	Instrument Cluster																																	V																							
Y	2014	Corvette	Body	Radio/HVAC Control																																																							
Y	2014	Corvette	Body	Inside Rearview Mirror																																																							
Y	2014	Corvette	Body	Radio																																																							
Y	2014	Corvette	Body	Amplifier																																																							
Y	2014	Corvette	Body	Human Machine Interface Control Module																																																							
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
Y	2014	Corvette	Body	HVAC Control Module																														V													V	V		V									
Y	2014	Corvette	Body	Seat Memory Control Module - Passenger																																																						
Y	2014	Corvette	Body	Seat Memory Control Module - Driver																																																							
Y	2014	Corvette	Body	Folding Top Control Module																																																						
Y	2014	Corvette	Body	Keyless Entry Control Module																																																						
Y	2014	Corvette	Body	Steering Column Lock Control Module																																																						
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																				V																																			
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																				V																																			
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																						
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Automatic Transmission																				V																																			
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Manual Transmission																				V																																			
Y	2015	Corvette	Powertrain	6.2L LT4 Transmission Control Module																																																						
Y	2015	Corvette	Powertrain	Chassis Control Module																																																						
Y	2015	Corvette	Chassis	Electronic Brake Control Module					V																																																	
Y	2015	Corvette	Chassis	Parking Brake Control Module																																																						
Y	2015	Corvette	Chassis	Power Steering Control Module	V	V	V																																																			
Y	2015	Corvette	Chassis	Steering Wheel Angle Sensor Module				V	V																																																
Y	2015	Corvette	Chassis	Suspension Control Module																																																					
Y	2015	Corvette	Body	Body Control Module Convertible						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																								V					
Y	2015	Corvette	Body	Body Control Module Coupe						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																								V					
Y	2015	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																						
Y	2015	Corvette	Body	Passenger Presence Module																																V																						
Y	2015	Corvette	Body	Instrument Cluster																																	V																					
Y	2015	Corvette	Body	Radio/HVAC Control																																																					
Y	2015	Corvette	Body	Vehicle Performance Data Recorder																																																					
Y	2015	Corvette	Body	Inside Rearview Mirror																																																					
Y	2015	Corvette	Body	Radio																																																					
Y	2015	Corvette	Body	Amplifier																																																					
Y	2015	Corvette	Body	Human Machine Interface Control Module																																																					
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
Y	2015	Corvette	Body	HVAC Control Module																														V													V	V		V									
Y	2015	Corvette	Body	Seat Memory Control Module - Passenger																																																						
Y	2015	Corvette	Body	Seat Memory Control Module - Driver																																																						
Y	2015	Corvette	Body	Folding Top Control Module																																																						
Y	2015	Corvette	Body	Keyless Entry Control Module																																																						
Y	2015	Corvette	Body	Steering Column Lock Control Module																																																						
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																				V																																			
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																				V																																			
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Automatic Transmission																				V																																			
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Manual Transmission																				V																																			
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Y	2016	Corvette	Powertrain	Rear Differential Clutch Control Module																																																								
Y	2016	Corvette	Chassis	Electronic Brake Control Module					V																																																			
Y	2016	Corvette	Chassis	Parking Brake Control Module																																																								
Y	2016	Corvette	Chassis	Power Steering Control Module																																																								
Y	2016	Corvette	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
Y	2016	Corvette	Chassis	Suspension Control Module																																																								
Y	2016	Corvette	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																														V				
Y	2016	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
Y	2016	Corvette	Body	Passenger Presence Module																															V																									
Y	2016	Corvette	Body	Instrument Cluster																																V																								
Y	2016	Corvette	Body	Radio/HVAC Control																																																								
Y	2016	Corvette	Body	Vehicle Performance Data Recorder																																																								
Y	2016	Corvette	Body	Video Processing Control Module																																																								
Y	2016	Corvette	Body	Inside Rearview Mirror																																																								
Y	2016	Corvette	Body	Radio																																																								
Y	2016	Corvette	Body	Amplifier																																																								
Y	2016	Corvette	Body	Human Machine Interface Control Module																																																								
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
Y	2016	Corvette	Body	HVAC Control Module																														V													V	V		V										
Y	2016	Corvette	Body	Liftgate Control Module																																																								
Y	2016	Corvette	Body	Seat Memory Control Module - Passenger																																																								
Y	2016	Corvette	Body	Seat Memory Control Module - Driver																																																								
Y	2016	Corvette	Body	Folding Top Control Module																																																								
Y	2016	Corvette	Body	Keyless Entry Control Module																																																								
Y	2016	Corvette	Body	Steering Column Lock Control Module																																																								
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																				V																																				
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																								
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																								
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																				V																																				
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																								
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																				V																																				
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																								
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																								
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																				V																																				
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																								
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																								
Y	2016	Cruze	Chassis	Electronic Brake Control Module					V																																																			
Y	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																								
Y	2016	Cruze	Chassis	Power Steering Control Module	V	V	V																																																					
Y	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
Y	2016	Cruze	Body	Body Control Module						V	V	V		V	V		V	V	V		V	V	V	V	V		V	V																													V				
Y	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
Y	2016	Cruze	Body	Passenger Presence Module																															V																									
Y	2016	Cruze	Body	Instrument Cluster																																V																								
Y	2016	Cruze	Body	Radio Controls																																																								
Y	2016	Cruze	Body	HVAC Controls																																																								
Y	2016	Cruze	Body	Trailer Interface Control Module																																V																								
Y	2016	Cruze	Body	Radio Base (IO3 IO7)																																																								
Y	2016	Cruze	Body	Radio (IOA)																																																								
Y	2016	Cruze	Body	Radio (IOB)																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Y	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																									
Y	2016	Cruze	Body	Amplifier																																																									
Y	2016	Cruze	Body	Multimedia Player Interface Module																																V																									
Y	2016	Cruze	Body	Human Machine Interface Control Module																																																									
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
Y	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V	V	V									
Y	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																														V												V	V	V	V									
Y	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																														V												V	V	V										
Y	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																														V												V	V	V	V									
Y	2016	Cruze	Body	Keyless Entry Control Module																																																									
Y	2016	Cruze	Body	Right Side Object Detection Control Module																																																									
Y	2016	Cruze	Body	Left Side Object Detection Control Module																																																									
Y	2016	Cruze	Body	Parking Assist Control Module																																V																									
Y	2016	Cruze	Body	Frontview Camera Module																																																									
Y	2016	Cruze	Body	Steering Column Lock Control Module																																																									
Y	2016	Cruze	Body	Long Range Radar Sensor Module																																																									
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																									
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																									
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Transmission Control Module																																																									
Z	2004	ALL	Chassis	Electronic Brake Control Module																																																									
Z	2004	ALL	Chassis	Power Steering Control Module																																																									
Z	2004	ALL	Body	Body Control Module																																																									
Z	2004	ALL	Body	Digital Radio Receiver																																																									
Z	2004	ALL	Body	HVAC Control Module																																																									
Z	2004	ALL	Body	Instrument Panel Cluster																																																									
Z	2004	ALL	Body	Radio																																																									
Z	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
Z	2004	ALL	Body	Theft Deterrent Module																																																									
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																									
Z	2005	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																									
Z	2005	ALL	Chassis	Electronic Brake Control Module																																																									
Z	2005	ALL	Chassis	Power Steering Control Module																																																									
Z	2005	ALL	Body	Body Control Module																																																									
Z	2005	ALL	Body	Digital Radio Receiver																																																									
Z	2005	ALL	Body	HVAC Control Module																																																									
Z	2005	ALL	Body	Instrument Panel Cluster																																																									
Z	2005	ALL	Body	Radio																																																									
Z	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
Z	2005	ALL	Body	Theft Deterrent Module																																																									
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																									
Z	2006	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																									
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																									
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																									
Z	2006	ALL	Chassis	Electronic Brake Control Module																																																									
Z	2006	ALL	Chassis	Power Steering Control Module																																																									
Z	2006	ALL	Body	Body Control Module																																																									
Z	2006	ALL	Body	Digital Radio Receiver																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Z	2006	ALL	Body	HVAC Control Module																																																								
Z	2006	ALL	Body	Instrument Panel Cluster																																																								
Z	2006	ALL	Body	Radio																																																								
Z	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2006	ALL	Body	Theft Deterrent Module																																																								
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																								
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																								
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
Z	2007	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2007	ALL	Chassis	Power Steering Control Module																																																								
Z	2007	ALL	Body	Body Control Module																																																								
Z	2007	ALL	Body	Digital Radio Receiver																																																								
Z	2007	ALL	Body	Disc Player and Video Display																																																								
Z	2007	ALL	Body	HVAC Control Module																																																								
Z	2007	ALL	Body	Instrument Panel Cluster																																																								
Z	2007	ALL	Body	Radio																																																								
Z	2007	ALL	Body	Remote Control Door Lock Receiver																																																								
Z	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2007	ALL	Body	Theft Deterrent Module																																																								
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																								
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																								
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																								
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																								
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																								
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
Z	2008	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2008	ALL	Chassis	Power Steering Control Module																																																								
Z	2008	ALL	Body	Body Control Module Classic																																																								
Z	2008	ALL	Body	Body Control Module Malibu																																																								
Z	2008	ALL	Body	Digital Radio Receiver																																																								
Z	2008	ALL	Body	Disc Player and Video Display																																																								
Z	2008	ALL	Body	HVAC Control Module Classic																																																								
Z	2008	ALL	Body	HVAC Control Module Malibu																																																								
Z	2008	ALL	Body	Instrument Panel Cluster Classic																																																								
Z	2008	ALL	Body	Instrument Panel Cluster Malibu																																																								
Z	2008	ALL	Body	Radio																																																								
Z	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
Z	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2008	ALL	Body	Theft Deterrent Module																																																								
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																								
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																								
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																								
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump																																																								
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump																																																								
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Without Tap Shift																																																										
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																											
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
Z	2009	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2009	ALL	Chassis	Power Steering Control Module																																																											
Z	2009	ALL	Body	Body Control Module																																																											
Z	2009	ALL	Body	Digital Radio Receiver																																																											
Z	2009	ALL	Body	Disc Player and Video Display																																																											
Z	2009	ALL	Body	HVAC Control Module																																																											
Z	2009	ALL	Body	Instrument Panel Cluster																																																											
Z	2009	ALL	Body	Personal Audio Link Module																																																											
Z	2009	ALL	Body	Radio																																																											
Z	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2009	ALL	Body	Theft Deterrent Module																																																											
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																											
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																											
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																											
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Engine Control Module																																																											
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 6 Speed																																																											
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 4 Speed																																																											
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																											
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																											
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
Z	2010	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2010	ALL	Chassis	Power Steering Control Module																																																											
Z	2010	ALL	Body	Body Control Module																																																											
Z	2010	ALL	Body	Digital Radio Receiver																																																											
Z	2010	ALL	Body	HVAC Control Module																																																											
Z	2010	ALL	Body	Instrument Panel Cluster																																																											
Z	2010	ALL	Body	Personal Audio Link Module																																																											
Z	2010	ALL	Body	Radio																																																											
Z	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2010	ALL	Body	Theft Deterrent Module																																																											
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																											
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																											
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																											
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																											
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
Z	2011	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2011	ALL	Chassis	Power Steering Control Module																																																											
Z	2011	ALL	Body	Body Control Module																																																											
Z	2011	ALL	Body	Digital Radio Receiver																																																											
Z	2011	ALL	Body	HVAC Control Module																																																											
Z	2011	ALL	Body	Instrument Panel Cluster																																																											
Z	2011	ALL	Body	Personal Audio Link Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Z	2011	ALL	Body	Radio																																																								
Z	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2011	ALL	Body	Theft Deterrent Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Engine Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Chassis	Electronic Brake Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Chassis	Power Steering Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Body	Body Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Body	Digital Radio Receiver																																																								
Z	2012	Malibu (Seventh Gen)	Body	HVAC Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Body	Instrument Panel Cluster																																																								
Z	2012	Malibu (Seventh Gen)	Body	Personal Audio Link Module																																																								
Z	2012	Malibu (Seventh Gen)	Body	Radio																																																								
Z	2012	Malibu (Seventh Gen)	Body	Supplemental Inflatable Restraint																																																								
Z	2012	Malibu (Seventh Gen)	Body	Theft Deterrent Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																				V																																				
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Manual Transmission																				V																																				
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Fuel Injector Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Transmission Control Module																																																V	V							
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Fuel Pump Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																				V																																				
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Fuel Pump Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																				
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	Rear Differential Clutch Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Electronic Brake Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Parking Brake Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Power Steering Control Module	V	V	V																																																					
Z	2012	Malibu (Eighth Gen)	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
Z	2012	Malibu (Eighth Gen)	Chassis	Suspension Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																									V								
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V								
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																									V	V	V	V	V	V	V																									
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																									V	V	V	V	V	V	V																									
Z	2012	Malibu (Eighth Gen)	Body	Passenger Presence Module																				V																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Z	2012	Malibu (Eighth Gen)	Body	Instrument Cluster																																V																								
Z	2012	Malibu (Eighth Gen)	Body	Head-Up Display Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Headlamp Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Radio																																																								
Z	2012	Malibu (Eighth Gen)	Body	Digital Radio Receiver Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Multimedia Player Interface Module																																V																								
Z	2012	Malibu (Eighth Gen)	Body	Mobile Telephone Control Module																																V																								
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Dual (CJ2)																														V												V	V	V	V	V									
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V									
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V									
Z	2012	Malibu (Eighth Gen)	Body	Rear Seat Heating Control Module																																						V	V																
Z	2012	Malibu (Eighth Gen)	Body	Keyless Entry Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Right Side Object Detection Control Module																																								V	V															
Z	2012	Malibu (Eighth Gen)	Body	Left Side Object Detection Control Module																																								V	V															
Z	2012	Malibu (Eighth Gen)	Body	Parking Assist Control Module																																V																								
Z	2012	Malibu (Eighth Gen)	Body	Vehicle Direction Camera Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Steering Column Lock Control Module																																																								
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Engine Control Module																				V																																				
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Transmission Control Module																																																								
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Engine Control Module																				V																																				
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 1																																																								
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 2																																																								
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module																				V																																				
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 6 Speed (MNM)																																																								
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 8 Speed (MRC)																																																				V	V				
Z	2016	Malibu	Chassis	Electronic Brake Control Module					V																																																			
Z	2016	Malibu	Chassis	Brake Booster Control Module																																																									
Z	2016	Malibu	Chassis	Power Steering Control Module	V	V	V																																																						
Z	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V																										V						
Z	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V		V	V	V		V	V	V	V	V	V	V	V	V																									V						
Z	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																								
Z	2016	Malibu	Body	Passenger Presence Module																																V																								
Z	2016	Malibu	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																V																								
Z	2016	Malibu	Body	Instrument Cluster Enhanced Monochrome Driver Info Center (UDC)																																V																								
Z	2016	Malibu	Body	Radio Controls																																																							
Z	2016	Malibu	Body	HVAC Controls																																																							
Z	2016	Malibu	Body	Active Safety Control Module																																																							
Z	2016	Malibu	Body	Headlamp Control Module																																																							
Z	2016	Malibu	Body	Radio Base																																																							
Z	2016	Malibu	Body	Radio (IOA)																																																							
Z	2016	Malibu	Body	Radio Uplevel (IO4 IO5 IO6)																																																							
Z	2016	Malibu	Body	Amplifier																																																							
Z	2016	Malibu	Body	Human Machine Interface Control Module																																																							
Z	2016	Malibu	Body	Navigation Control Module																																																							
Z	2016	Malibu	Body	Mobile Telephone Control Module																																V																								
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
Z	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																														V												V	V		V									
Z	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																														V												V	V		V									
Z	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																														V												V	V		V									
Z	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																														V												V	V		V									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
Z	2016	Malibu	Body	Electric A/C Compressor Control Module																																																								
Z	2016	Malibu	Body	Seat Memory Control Module - Driver																																																								
Z	2016	Malibu	Body	Keyless Entry Control Module																																																								
Z	2016	Malibu	Body	Right Side Object Detection Control Module																																																								
Z	2016	Malibu	Body	Left Side Object Detection Control Module																																																								
Z	2016	Malibu	Body	Parking Assist Control Module																																V																								
Z	2016	Malibu	Body	Frontview Camera Module																																																								
Z	2016	Malibu	Body	Frontview Camera Module																																																								
Z	2016	Malibu	Body	Steering Column Lock Control Module																																																								
Z	2016	Malibu	Body	Long Range Radar Sensor Module																																																								
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																				V																																				
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																				V																																				
1	2013	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																								
1	2013	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																								
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																								
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																								
1	2013	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																V	V							
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Automatic Transmission																																																								
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Manual Transmission																																																								
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																								
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																								
1	2013	Malibu	Powertrain	2.0L LTD Fuel Pump Control Module																																																								
1	2013	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																								
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																				V																																				
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																				V																																				
1	2013	Malibu	Powertrain	(X) 2.0L LTG Fuel Pump Control Module																																																				V				
1	2013	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																				
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
1	2013	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																								
1	2013	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																								
1	2013	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																								
1	2013	Malibu	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																		V	V					
1	2013	Malibu	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																				V																																			V	V
1	2013	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																								
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																				
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
1	2013	Malibu	Powertrain	(A) 2.5L LCV Fuel Pump Control Module																																																			V					
1	2013	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																				
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
1	2013	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
1	2013	Malibu	Chassis	Electronic Brake Control Module																																																								
1	2013	Malibu	Chassis	Parking Brake Control Module																																																								
1	2013	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																								
1	2013	Malibu	Chassis	Power Steering Control Module	V	V	V																																																					
1	2013	Malibu	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
1	2013	Malibu	Chassis	Suspension Control Module																																																								
1	2013	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V									
1	2013	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V									
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																										V	V	V	V	V	V	V																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																									V	V	V	V	V	V	V																								
1	2013	Malibu	Body	Passenger Presence Module																																V																								
1	2013	Malibu	Body	Instrument Cluster																																	V																							
1	2013	Malibu	Body	Headlamp Control Module																																																							
1	2013	Malibu	Body	Radio																																																							
1	2013	Malibu	Body	Digital Radio Receiver Control Module																																																							
1	2013	Malibu	Body	Multimedia Player Interface Module																																	V																							
1	2013	Malibu	Body	Mobile Telephone Control Module																																	V																							
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																			
1	2013	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																														V											V	V	V	V	V								
1	2013	Malibu	Body	HVAC Control Module Auto Single (C68)																														V											V	V	V	V	V								
1	2013	Malibu	Body	HVAC Control Module Manual Single (C67)																														V											V	V	V	V	V								
1	2013	Malibu	Body	Rear Seat Heating Control Module																																							V	V														
1	2013	Malibu	Body	Keyless Entry Control Module																																																						
1	2013	Malibu	Body	Parking Assist Control Module																																	V																							
1	2013	Malibu	Body	Vehicle Direction Camera Control Module																																																						
1	2013	Malibu	Body	Steering Column Lock Control Module																																																						
1	2013	Malibu	Body	Battery Energy Control Module																																																						
1	2014	Impala	Powertrain	(R) 2.4L LUK Engine Control Module																																																						
1	2014	Impala	Powertrain	(R) 2.4L LUK Transmission Control Module																																																						
1	2014	Impala	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																						
1	2014	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																				V																																			
1	2014	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																						
1	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																			
1	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																						
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																			V	V		
1	2014	Impala	Chassis	Electronic Brake Control Module					V																																																	
1	2014	Impala	Chassis	Distance Sensing Cruise Control Module																																																						
1	2014	Impala	Chassis	Parking Brake Control Module																																																						
1	2014	Impala	Chassis	Power Steering Control Module	V	V																																																					
1	2014	Impala	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
1	2014	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V	V		V	V	V	V	V		V	V																								V							
1	2014	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V	V		V	V	V	V	V		V	V																								V							
1	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
1	2014	Impala	Body	Passenger Presence Module																																V																							
1	2014	Impala	Body	Instrument Cluster																																	V																							
1	2014	Impala	Body	Radio Control																																																						
1	2014	Impala	Body	HVAC Control																																																						
1	2014	Impala	Body	Radio																																																						
1	2014	Impala	Body	Amplifier																																																						
1	2014	Impala	Body	Human Machine Interface Control Module																																																						
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																			
1	2014	Impala	Body	HVAC Control Module																														V											V	V	V		V								
1	2014	Impala	Body	Keyless Entry Control Module																																																						
1	2014	Impala	Body	Right Side Object Detection Control Module																																																						
1	2014	Impala	Body	Left Side Object Detection Control Module																																																						
1	2014	Impala	Body	Parking Assist Control Module																																	V																							
1	2014	Impala	Body	Frontview Camera Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2014	Impala	Body	Steering Column Lock Control Module																																																										
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																				V																																						
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																				V																																						
1	2014	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
1	2014	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																										
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
1	2014	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																			V	V					
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
1	2014	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																										
1	2014	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																										
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																				V																																						
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																				V																																						
1	2014	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																							V		
1	2014	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																						
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2014	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2014	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																										
1	2014	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																					V	V				
1	2014	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																										
1	2014	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																										
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																				V																																						
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																										
1	2014	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																						V			
1	2014	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																										
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																						
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
1	2014	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
1	2014	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2014	Malibu	Chassis	Parking Brake Control Module																																																										
1	2014	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2014	Malibu	Chassis	Power Steering Control Module	V	V	V																																																							
1	2014	Malibu	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
1	2014	Malibu	Chassis	Suspension Control Module																																																										
1	2014	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V								
1	2014	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V								
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																									V	V	V	V	V	V	V																									
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																									V	V	V	V	V	V	V																									
1	2014	Malibu	Body	Passenger Presence Module																																V																									
1	2014	Malibu	Body	Instrument Cluster																																	V																							
1	2014	Malibu	Body	Headlamp Control Module																																																									
1	2014	Malibu	Body	Radio																																																									
1	2014	Malibu	Body	Digital Radio Receiver Control Module																																																									
1	2014	Malibu	Body	Multimedia Player Interface Module																																	V																							
1	2014	Malibu	Body	Mobile Telephone Control Module																																	V																							
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																			
1	2014	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																															V											V	V	V	V	V								
1	2014	Malibu	Body	HVAC Control Module Auto Single (C68)																															V											V	V	V	V	V								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2014	Malibu	Body	HVAC Control Module Manual Single (C67)																															V												V	V	V	V	V								
1	2014	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																															V												V	V	V	V	V								
1	2014	Malibu	Body	Rear Seat Heating Control Module																																							V	V															
1	2014	Malibu	Body	Keyless Entry Control Module																																																							
1	2014	Malibu	Body	Left Side Object Detection Control Module																																																							
1	2014	Malibu	Body	Parking Assist Control Module																																V																							
1	2014	Malibu	Body	Frontview Camera Module																																																						
1	2014	Malibu	Body	Steering Column Lock Control Module																																																						
1	2015	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																				V																																		
1	2015	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																						
1	2015	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																				V																																		
1	2015	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																						
1	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																		
1	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																						
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																			V	V		
1	2015	Impala	Chassis	Electronic Brake Control Module					V																																																	
1	2015	Impala	Chassis	Distance Sensing Cruise Control Module																																																						
1	2015	Impala	Chassis	Parking Brake Control Module																																																						
1	2015	Impala	Chassis	Power Steering Control Module	V	V																																																					
1	2015	Impala	Chassis	Power Steering Control Module																																																						
1	2015	Impala	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
1	2015	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V	V	V		V	V	V	V	V		V	V																							V							
1	2015	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V	V	V		V	V	V	V	V		V	V																							V							
1	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
1	2015	Impala	Body	Passenger Presence Module																																V																							
1	2015	Impala	Body	Instrument Cluster																																	V																						
1	2015	Impala	Body	Radio Control																																																						
1	2015	Impala	Body	HVAC Control																																																						
1	2015	Impala	Body	Radio																																																						
1	2015	Impala	Body	Amplifier																																																						
1	2015	Impala	Body	Human Machine Interface Control Module																																																						
1	2015	Impala	Body	Telematics Communication Interface Control Module																																	V	V	V																				
1	2015	Impala	Body	HVAC Control Module																															V												V	V	V		V								
1	2015	Impala	Body	Keyless Entry Control Module																																																						
1	2015	Impala	Body	Right Side Object Detection Control Module																																																						
1	2015	Impala	Body	Left Side Object Detection Control Module																																																						
1	2015	Impala	Body	Parking Assist Control Module																																V																							
1	2015	Impala	Body	Frontview Camera Module																																																						
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																				V																																		
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																				V																																		
1	2015	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																						
1	2015	Malibu	Powertrain	2.0L LBN Chassis Control Module																																																			V		
1	2015	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																						
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																						
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																						
1	2015	Malibu	Powertrain	2.0L LBS Chassis Control Module																																																			V		
1	2015	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																	V	V				
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																						
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																						
1	2015	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																			V		

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2015	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																										
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																				V																																						
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																				V																																						
1	2015	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																										V	
1	2015	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																						
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
1	2015	Malibu	Powertrain	2.4L LE9 Chassis Control Module																																																										V	
1	2015	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																											
1	2015	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2015	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																										V	
1	2015	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																				V																														V								V
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																											
1	2015	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																										V	
1	2015	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Automatic Transmission																				V																																						
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Manual Transmission																																																											
1	2015	Malibu	Powertrain	3.0L LFW Chassis Control Module																																																										V	
1	2015	Malibu	Powertrain	3.0L LFW Transmission Control Module																																																											
1	2015	Malibu	Powertrain	Rear Differential Clutch Control Module																																																											
1	2015	Malibu	Chassis	Electronic Brake Control Module																																																											
1	2015	Malibu	Chassis	Parking Brake Control Module																																																											
1	2015	Malibu	Chassis	Power Steering Control Module	V	V	V																																																								
1	2015	Malibu	Chassis	Steering Wheel Angle Sensor Module				V	V																																																						
1	2015	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																																			
1	2015	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																																			
1	2015	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																											
1	2015	Malibu	Body	Passenger Presence Module																																V																											
1	2015	Malibu	Body	Instrument Cluster																																	V																										
1	2015	Malibu	Body	Headlamp Control Module																																																											
1	2015	Malibu	Body	Radio																																																											
1	2015	Malibu	Body	Digital Radio Receiver Control Module																																																											
1	2015	Malibu	Body	Multimedia Player Interface Module																																	V																										
1	2015	Malibu	Body	Mobile Telephone Control Module																																	V																										
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																		V	V	V																							
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																							
1	2015	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																														V												V	V	V	V	V												
1	2015	Malibu	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V												
1	2015	Malibu	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V												
1	2015	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																														V												V	V	V	V	V												
1	2015	Malibu	Body	Front Seat Heating Control Module																																					V	V																					
1	2015	Malibu	Body	Rear Seat Heating Control Module																																							V	V																			
1	2015	Malibu	Body	Keyless Entry Control Module																																																											
1	2015	Malibu	Body	Left Side Object Detection Control Module																																																											
1	2015	Malibu	Body	Parking Assist Control Module																																	V																										
1	2015	Malibu	Body	Frontview Camera Module																																																											
1	2015	Malibu	Body	Steering Column Lock Control Module																																																											
1	2015	Malibu (LSG)	Powertrain	1.6L LLU Engine Control Module																																																											
1	2015	Malibu (LSG)	Powertrain	Transmission Control Module																																																											
1	2015	Malibu (LSG)	Powertrain	Rear Differential Clutch Control Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2015	Malibu (LSG)	Chassis	Electronic Brake Control Module					V																																																			
1	2015	Malibu (LSG)	Chassis	Parking Brake Control Module																																																								
1	2015	Malibu (LSG)	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
1	2015	Malibu (LSG)	Chassis	Suspension Control Module																																																								
1	2015	Malibu (LSG)	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V						
1	2015	Malibu (LSG)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
1	2015	Malibu (LSG)	Body	Instrument Cluster																																	V																						
1	2015	Malibu (LSG)	Body	Headlamp Control Module																																																							
1	2015	Malibu (LSG)	Body	Radio																																																							
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 9.7																																		V	V	V																		
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
1	2015	Malibu (LSG)	Body	HVAC Control Module																														V												V	V	V	V	V								
1	2015	Malibu (LSG)	Body	Front Seat Heating Control Module																																					V	V																
1	2015	Malibu (LSG)	Body	Keyless Entry Control Module																																																						
1	2015	Malibu (LSG)	Body	Left Side Object Detection Control Module																																																						
1	2015	Malibu (LSG)	Body	Parking Assist Control Module																																	V																						
1	2015	Malibu (LSG)	Body	Frontview Camera Module																																																						
1	2015	Malibu (LSG)	Body	Steering Column Lock Control Module																																																						
1	2016	Impala	Powertrain	(A) 2.5L LCV Engine Control Module																				V																																		
1	2016	Impala	Powertrain	(A) 2.5L LCV Transmission Control Module																																																						
1	2016	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																				V																																		
1	2016	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																					
1	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																		
1	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																					
1	2016	Impala	Powertrain	Chassis Control Module																																																		V	V		
1	2016	Impala	Chassis	Electronic Brake Control Module					V																																																	
1	2016	Impala	Chassis	Distance Sensing Cruise Control Module																																																						
1	2016	Impala	Chassis	Parking Brake Control Module																																																						
1	2016	Impala	Chassis	Power Steering Control Module	V	V																																																				
1	2016	Impala	Chassis	Power Steering Control Module			V																																																			
1	2016	Impala	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
1	2016	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V	V	V		V	V	V	V	V		V	V																								V						
1	2016	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V	V	V		V	V	V	V	V		V	V																								V						
1	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
1	2016	Impala	Body	Passenger Presence Module																																V																						
1	2016	Impala	Body	Instrument Cluster																																	V																						
1	2016	Impala	Body	Radio Control																																																						
1	2016	Impala	Body	HVAC Control																																																						
1	2016	Impala	Body	Radio																																																						
1	2016	Impala	Body	Amplifier																																																						
1	2016	Impala	Body	Human Machine Interface Control Module																																																						
1	2016	Impala	Body	Navigation Control Module																																																						
1	2016	Impala	Body	Telematics Communication Interface Control Module																																		V	V	V																		
1	2016	Impala	Body	HVAC Control Module																														V												V	V	V		V								
1	2016	Impala	Body	Seat Memory Control Module - Driver																																																						
1	2016	Impala	Body	Keyless Entry Control Module																																																						
1	2016	Impala	Body	Right Side Object Detection Control Module																																																						
1	2016	Impala	Body	Left Side Object Detection Control Module																																																						
1	2016	Impala	Body	Parking Assist Control Module																																	V																						
1	2016	Impala	Body	Frontview Camera Module																																																						
1	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																						
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																						
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2016	Malibu	Powertrain	Fuel Injector Control Module					V																																																					
1	2016	Malibu	Powertrain	Chassis Control Module																																																								V		
1	2016	Malibu	Chassis	Electronic Brake Control Module					V																																																					
1	2016	Malibu	Chassis	Parking Brake Control Module																																																										
1	2016	Malibu	Chassis	Power Steering Control Module	V	V	V																																																							
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																										V							
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																										V							
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
1	2016	Malibu	Body	Passenger Presence Module																																V																										
1	2016	Malibu	Body	Instrument Cluster																																	V																									
1	2016	Malibu	Body	Headlamp Control Module																																																										
1	2016	Malibu	Body	Radio																																																									
1	2016	Malibu	Body	Digital Radio Receiver Control Module																																																									
1	2016	Malibu	Body	Multimedia Player Interface Module																																	V																								
1	2016	Malibu	Body	Mobile Telephone Control Module																																	V																								
1	2016	Malibu	Body	Telematics Communication Interface Control Module																																		V	V	V																				
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																														V													V	V		V								
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																														V													V	V		V								
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																														V													V	V		V								
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																														V													V	V		V								
1	2016	Malibu	Body	Seat Memory Control Module																																																									
1	2016	Malibu	Body	Front Seat Heating Control Module																																						V	V																		
1	2016	Malibu	Body	Rear Seat Heating Control Module																																								V	V																
1	2016	Malibu	Body	Keyless Entry Control Module																																																									
1	2016	Malibu	Body	Left Side Object Detection Control Module																																																									
1	2016	Malibu	Body	Parking Assist Control Module																																	V																								
1	2016	Malibu	Body	Frontview Camera Module																																																									

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
A	2016	Cobalt	Body	Front Seat Heating Control Module																																																											
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																										
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																										
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2010	Beat	Powertrain	Transmission Control Module																																																										
B	2010	Beat	Chassis	Electronic Brake Control Module																																																										
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2010	Beat	Chassis	Power Steering Control Module																																																										
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2010	Beat	Body	Instrument Cluster																																																										
B	2010	Beat	Body	Keyless Entry Control Module																																																										
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																										
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																										
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2011	Beat	Powertrain	Transmission Control Module																																																										
B	2011	Beat	Chassis	Electronic Brake Control Module																																																										
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2011	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2011	Beat	Body	Instrument Cluster																																																										
B	2011	Beat	Body	Keyless Entry Control Module																																																										
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2012	Beat	Powertrain	Transmission Control Module																																																										
B	2012	Beat	Chassis	Electronic Brake Control Module																																																										
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2012	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2012	Beat	Body	Instrument Cluster																																																										
B	2012	Beat	Body	Keyless Entry Control Module																																																										
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2013	Beat	Powertrain	Transmission Control Module																																																										
B	2013	Beat	Chassis	Electronic Brake Control Module																																																										
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2013	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2013	Beat	Body	Instrument Cluster																																																										
B	2013	Beat	Body	Keyless Entry Control Module																																																										
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2014	Beat	Powertrain	Transmission Control Module																																																										
B	2014	Beat	Powertrain	Fuel Injector Control Module																																																										
B	2014	Beat	Chassis	Electronic Brake Control Module																																																										
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
B	2016	Cruze	Body	HVAC Controls																																																											
B	2016	Cruze	Body	Trailer Interface Control Module																																																											
B	2016	Cruze	Body	Radio Base (IO3 IO7)																		V	V																																								
B	2016	Cruze	Body	Radio (IOA)																																																											
B	2016	Cruze	Body	Radio (IOB)																																																											
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																		V	V																																								
B	2016	Cruze	Body	Amplifier																				V	V																																						
B	2016	Cruze	Body	Multimedia Player Interface Module																																																											
B	2016	Cruze	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																	
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																											
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																											
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																											
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																											
B	2016	Cruze	Body	Keyless Entry Control Module																																																											
B	2016	Cruze	Body	Right Side Object Detection Control Module																																																											
B	2016	Cruze	Body	Left Side Object Detection Control Module																																																											
B	2016	Cruze	Body	Parking Assist Control Module																																																											
B	2016	Cruze	Body	Frontview Camera Module																											V	V																															
B	2016	Cruze	Body	Steering Column Lock Control Module																																																											
B	2016	Cruze	Body	Long Range Radar Sensor Module																																																											
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2010	Spark	Powertrain	Transmission Control Module																																																											
C	2010	Spark	Chassis	Electronic Brake Control Module																																																											
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2010	Spark	Chassis	Electric Power Steering Control Module																																																											
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2010	Spark	Body	Passenger Presence Module																																																											
C	2010	Spark	Body	Instrument Cluster																																																											
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																											
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																											
C	2011	Spark	Powertrain	Transmission Control Module																																																											
C	2011	Spark	Chassis	Electronic Brake Control Module																																																											
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2011	Spark	Chassis	Electric Power Steering Control Module																																																											
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2011	Spark	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2011	Spark	Body	Instrument Cluster																																																											
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																											
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																											
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																											
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																											
C	2012	Spark	Powertrain	Transmission Control Module																																																											
C	2012	Spark	Chassis	Electronic Brake Control Module																																																											
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2012	Spark	Chassis	Electric Power Steering Control Module																																																											
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2012	Spark	Body	Passenger Presence Module																																																											
C	2012	Spark	Body	Instrument Cluster																																																											
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																											
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																											
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																													V																														
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																													V																														
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																											
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																											
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2013	Spark	Powertrain	Fuel Injector Control Module																																																											
C	2013	Spark	Chassis	Electronic Brake Control Module																																																											
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2013	Spark	Chassis	Power Steering Control Module																																																											
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2013	Spark	Body	Body Control Module																																																											
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2013	Spark	Body	Passenger Presence Module																																																											
C	2013	Spark	Body	Instrument Cluster																																																											
C	2013	Spark	Body	Radio																																																											
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																											
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2015	Spark	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2015	Spark	Chassis	Power Steering Control Module																																																										
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2015	Spark	Body	Body Control Module																																																									
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark	Body	Passenger Presence Module																																																										
D	2015	Spark	Body	Instrument Cluster																																																									
D	2015	Spark	Body	Instrument Cluster																																																									
D	2015	Spark	Body	Tire Pressure Indicator Module																																																										
D	2015	Spark	Body	Radio																																																									
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2015	Spark	Body	Keyless Entry Control Module																																																										
D	2015	Spark EV	Powertrain	Engine Control Module																																																										
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module			V																																																						
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2				V		V																																																			
D	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
D	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
D	2015	Spark EV	Chassis	Power Steering Control Module																																																										
D	2015	Spark EV	Body	Body Control Module																	V																																								
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark EV	Body	Passenger Presence Module																																																										
D	2015	Spark EV	Body	Instrument Cluster																																																										
D	2015	Spark EV	Body	Radio																																																									
D	2015	Spark EV	Body	HVAC Control Module																																																										
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
D	2015	Spark EV	Body	Coolant Heater Control Module																																																										
D	2015	Spark EV	Body	Keyless Entry Control Module																																																										
D	2015	Spark EV	Body	Battery Charger Control Module																																																										
D	2015	Spark EV	Body	DC Charging Control Module																																																										
D	2015	Spark EV	Body	Battery Energy Control Module						V																																																			

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																												
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2011	Camaro	Chassis	Electronic Brake Control Module											V	V	V	V	V																																													
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2011	Camaro	Chassis	Power Steering Control Module																																																												
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2011	Camaro	Body	Passenger Presence Module																																																												
F	2011	Camaro	Body	Instrument Cluster																																																												
F	2011	Camaro	Body	Head-Up Display Module																																																												
F	2011	Camaro	Body	Auxiliary Gage Module																																																												
F	2011	Camaro	Body	Headlamp Control Module																															V																														
F	2011	Camaro	Body	Radio																																																											
F	2011	Camaro	Body	Multimedia Player Interface Module																																																												
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																			V																																								
F	2011	Camaro	Body	Mobile Telephone Control Module																																																												
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																												
F	2011	Camaro	Body	Front Seat Heating Control Module																																																												
F	2011	Camaro	Body	Folding Top Control Module																																						V																					
F	2011	Camaro	Body	Parking Assist Control Module																																								V	V	V															
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																												
F	2012	Camaro	Chassis	Electronic Brake Control Module											V	V	V	V	V																																														
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2012	Camaro	Chassis	Power Steering Control Module																																																												
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2012	Camaro	Chassis	Suspension Control Module																																																												
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2012	Camaro	Body	Passenger Presence Module																																																												
F	2012	Camaro	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
F	2012	Camaro	Body	Head-Up Display Module																																																													
F	2012	Camaro	Body	Auxiliary Gage Module																																																													
F	2012	Camaro	Body	Headlamp Control Module																															V																														
F	2012	Camaro	Body	Radio																																																											
F	2012	Camaro	Body	Multimedia Player Interface Module																																																												
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																			V																																								
F	2012	Camaro	Body	Mobile Telephone Control Module																																																												
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																											
F	2012	Camaro	Body	Front Seat Heating Control Module																																																											
F	2012	Camaro	Body	Folding Top Control Module																																						V																					
F	2012	Camaro	Body	Parking Assist Control Module																																							V	V	V																
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump																																																											
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow																																																											
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump																																																											
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow																																																											
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																											
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump																																																											
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow																																																											
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump																																																											
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow																																																											
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																											
F	2013	Camaro	Chassis	Electronic Brake Control Module											V	V	V	V	V																																													
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2013	Camaro	Chassis	Power Steering Control Module																																																											
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2013	Camaro	Chassis	Suspension Control Module																																																											
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																	V	V																								
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																	V	V																								
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2013	Camaro	Body	Passenger Presence Module																																																											
F	2013	Camaro	Body	Instrument Cluster																																																											
F	2013	Camaro	Body	Head-Up Display Module																																																											
F	2013	Camaro	Body	Auxiliary Gage Module																																																											
F	2013	Camaro	Body	Headlamp Control Module																															V																												
F	2013	Camaro	Body	Radio																																																											
F	2013	Camaro	Body	Multimedia Player Interface Module																																																											
F	2013	Camaro	Body	Mobile Telephone Control Module																																																											
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
F	2013	Camaro	Body	HVAC Control Module																																																												
F	2013	Camaro	Body	Front Seat Heating Control Module																																																												
F	2013	Camaro	Body	Folding Top Control Module																																					V																						
F	2013	Camaro	Body	Parking Assist Control Module																																							V	V	V																
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																											
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																											
F	2014	Camaro	Powertrain	Transmission Control Module																																																											
F	2014	Camaro	Chassis	Electronic Brake Control Module											V	V	V	V	V																																													
F	2014	Camaro	Chassis	Parking Brake Control Module																																																											
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2014	Camaro	Chassis	Power Steering Control Module																																																											
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2014	Camaro	Chassis	Suspension Control Module																																																											
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																	V																V	V																								
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																	V																V	V																								
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2014	Camaro	Body	Passenger Presence Module																																																											
F	2014	Camaro	Body	Instrument Cluster																																																											
F	2014	Camaro	Body	Head-Up Display Module																																																											
F	2014	Camaro	Body	Auxiliary Gage Module																																																											
F	2014	Camaro	Body	Headlamp Control Module																															V																												
F	2014	Camaro	Body	Radio																																																										
F	2014	Camaro	Body	Mobile Telephone Control Module																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2014	Camaro	Body	HVAC Control Module																																																											
F	2014	Camaro	Body	Front Seat Heating Control Module																																																											
F	2014	Camaro	Body	Folding Top Control Module																																					V																						
F	2014	Camaro	Body	Parking Assist Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module																													V																														
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2014	SS	Powertrain	Chassis Control Module																																																											
F	2014	SS	Chassis	Electronic Brake Control Module											V	V	V	V	V																																												
F	2014	SS	Chassis	Parking Brake Control Module																																																											
F	2014	SS	Chassis	Power Steering Control Module																																																											
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2014	SS	Body	Body Control Module																	V																																									
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2014	SS	Body	Passenger Presence Module																																																											
F	2014	SS	Body	Instrument Cluster																																																											
F	2014	SS	Body	Head-Up Display Module																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
F	2014	SS	Body	Radio Control																																																											
F	2014	SS	Body	HVAC Control																																																											
F	2014	SS	Body	Headlamp Control Module																															V					V																							
F	2014	SS	Body	Trailer Interface Control Module																																																											
F	2014	SS	Body	Radio																																																											
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2014	SS	Body	HVAC Control Module																																																											
F	2014	SS	Body	Seat Memory Control Module - Driver																																																											
F	2014	SS	Body	Keyless Entry Control Module																																																											
F	2014	SS	Body	Right Side Object Detection Control Module																																																											
F	2014	SS	Body	Left Side Object Detection Control Module																																																											
F	2014	SS	Body	Parking Assist Control Module																																						V																					
F	2014	SS	Body	Frontview Camera Module																											V																																
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																											
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																											
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																											
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																											
F	2015	Camaro	Powertrain	Transmission Control Module																																																											
F	2015	Camaro	Chassis	Electronic Brake Control Module											V	V	V	V	V																																												
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2015	Camaro	Chassis	Power Steering Control Module																																																											
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2015	Camaro	Chassis	Suspension Control Module																																																											
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																	V																V	V																									
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																	V																V	V																									
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2015	Camaro	Body	Passenger Presence Module																																																											
F	2015	Camaro	Body	Instrument Cluster																																																											
F	2015	Camaro	Body	Head-Up Display Module																																																											
F	2015	Camaro	Body	Auxiliary Gage Module																																																											
F	2015	Camaro	Body	Headlamp Control Module																															V																												
F	2015	Camaro	Body	Radio																																																											
F	2015	Camaro	Body	Mobile Telephone Control Module																																																											
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6																																																											
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																											
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2015	Camaro	Body	HVAC Control Module																																																											
F	2015	Camaro	Body	Front Seat Heating Control Module																																																											
F	2015	Camaro	Body	Folding Top Control Module																																					V																						
F	2015	Camaro	Body	Parking Assist Control Module																																																											
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2015	SS	Powertrain	Fuel Injector Control Module																																																												
F	2015	SS	Powertrain	Chassis Control Module																																																												
F	2015	SS	Chassis	Electronic Brake Control Module										V	V	V	V	V																																														
F	2015	SS	Chassis	Parking Brake Control Module																																																												
F	2015	SS	Chassis	Power Steering Control Module																																																												
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2015	SS	Chassis	Suspension Control Module																																														V														
F	2015	SS	Body	Body Control Module																	V																																											
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2015	SS	Body	Passenger Presence Module																																																												
F	2015	SS	Body	Instrument Cluster																																																												
F	2015	SS	Body	Head-Up Display Module																																																												
F	2015	SS	Body	Radio Control																																																												
F	2015	SS	Body	HVAC Control																																																												
F	2015	SS	Body	Headlamp Control Module																														V					V																									
F	2015	SS	Body	Trailer Interface Control Module																																																												
F	2015	SS	Body	Radio																																																												
F	2015	SS	Body	Telematics Communication Interface Control Module																																																												
F	2015	SS	Body	HVAC Control Module																																																												
F	2015	SS	Body	Seat Memory Control Module - Driver																																																												
F	2015	SS	Body	Keyless Entry Control Module																																																												
F	2015	SS	Body	Right Side Object Detection Control Module																																																												
F	2015	SS	Body	Left Side Object Detection Control Module																																																												
F	2015	SS	Body	Parking Assist Control Module																																						V																						
F	2015	SS	Body	Frontview Camera Module																											V																																	
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																														V		V																												
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																														V		V																												
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																												
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																												
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																												
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																												
F	2016	Camaro	Powertrain	Transmission Control Module																																																												
F	2016	Camaro	Chassis	Electronic Brake Control Module										V	V	V	V	V																																														
F	2016	Camaro	Chassis	Parking Brake Control Module																																																												
F	2016	Camaro	Chassis	Power Steering Control Module																																																												
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2016	Camaro	Chassis	Suspension Control Module																																														V														
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)									V																								V	V																										
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)									V																								V	V																										
F	2016	Camaro	Body	Serial Data Gateway Module																																																												
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2016	Camaro	Body	Passenger Presence Module																																																												
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																												
F	2016	Camaro	Body	Head-Up Display Module																																																												
F	2016	Camaro	Body	Auxiliary Gage Module																																																												
F	2016	Camaro	Body	Radio Controls																																																												
F	2016	Camaro	Body	HVAC Controls																																																												
F	2016	Camaro	Body	Vehicle Performance Data Recorder																																																												
F	2016	Camaro	Body	Radio																		V	V																																									

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
F	2016	Camaro	Body	Amplifier																				V	V																																				
F	2016	Camaro	Body	Media Disc Player																																																								
F	2016	Camaro	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																															
F	2016	Camaro	Body	Navigation Control Module																																																								
F	2016	Camaro	Body	Mobile Telephone Control Module																																																								
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																								
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)																																																								
F	2016	Camaro	Body	Seat Memory Control Module - Driver																																																								
F	2016	Camaro	Body	Folding Top Control Module																																						V																			
F	2016	Camaro	Body	Keyless Entry Control Module																																																								
F	2016	Camaro	Body	Right Side Object Detection Control Module																																																								
F	2016	Camaro	Body	Left Side Object Detection Control Module																																																								
F	2016	Camaro	Body	Parking Assist Control Module																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2016	SS	Powertrain	Fuel Injector Control Module																																																								
F	2016	SS	Chassis	Electronic Brake Control Module											V	V	V	V	V																																										
F	2016	SS	Chassis	Parking Brake Control Module																																																								
F	2016	SS	Chassis	Power Steering Control Module																																																								
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2016	SS	Chassis	Suspension Control Module																																													V											
F	2016	SS	Body	Body Control Module									V								V																																							
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2016	SS	Body	Passenger Presence Module																																																								
F	2016	SS	Body	Instrument Cluster																																																								
F	2016	SS	Body	Head-Up Display Module																																																								
F	2016	SS	Body	Radio Control																																																								
F	2016	SS	Body	HVAC Control																																																								
F	2016	SS	Body	Trailer Interface Control Module																																																								
F	2016	SS	Body	Radio																																																								
F	2016	SS	Body	Telematics Communication Interface Control Module																																																								
F	2016	SS	Body	HVAC Control Module																																																								
F	2016	SS	Body	Seat Memory Control Module - Driver																																																								
F	2016	SS	Body	Keyless Entry Control Module																																																								
F	2016	SS	Body	Right Side Object Detection Control Module																																																								
F	2016	SS	Body	Left Side Object Detection Control Module																																																								
F	2016	SS	Body	Parking Assist Control Module																																							V																	
F	2016	SS	Body	Frontview Camera Module																										V	V																														
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																													V																											
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																													V																											
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
G	2016	Malibu	Powertrain	Fuel Injector Control Module										V	V	V	V	V																																										
G	2016	Malibu	Powertrain	Chassis Control Module																																																								
G	2016	Malibu	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																									

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
G	2016	Malibu	Chassis	Parking Brake Control Module																																																												
G	2016	Malibu	Chassis	Power Steering Control Module																																																												
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																												
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)									V								V																																										
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)									V								V																																										
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2016	Malibu	Body	Passenger Presence Module																																																												
G	2016	Malibu	Body	Instrument Cluster																																																												
G	2016	Malibu	Body	Headlamp Control Module																															V				V																								
G	2016	Malibu	Body	Radio																																																											
G	2016	Malibu	Body	Digital Radio Receiver Control Module																																																												
G	2016	Malibu	Body	Multimedia Player Interface Module																																																												
G	2016	Malibu	Body	Mobile Telephone Control Module																																																												
G	2016	Malibu	Body	Telematics Communication Interface Control Module																																																												
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																												
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																												
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																												
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																												
G	2016	Malibu	Body	Seat Memory Control Module																																																												
G	2016	Malibu	Body	Front Seat Heating Control Module																																																												
G	2016	Malibu	Body	Rear Seat Heating Control Module																																																												
G	2016	Malibu	Body	Keyless Entry Control Module																																																												
G	2016	Malibu	Body	Left Side Object Detection Control Module																																																												
G	2016	Malibu	Body	Parking Assist Control Module																																																												
G	2016	Malibu	Body	Frontview Camera Module																											V	V																																
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																												
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																												
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																												
H	2010	Sail	Powertrain	Transmission Control Module																																																												
H	2010	Sail	Chassis	Electronic Brake Control Module																																																												
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																												
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																												
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																												
H	2011	Sail	Powertrain	Transmission Control Module																																																												
H	2011	Sail	Chassis	Electronic Brake Control Module																																																												
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																												
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																												
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																												
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																												
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																												
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																												
H	2012	Sail	Powertrain	Transmission Control Module																																																												
H	2012	Sail	Chassis	Electronic Brake Control Module																																																												
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																												
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																												
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																													V																													
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																									
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
J	2011	Cruze	Chassis	Electronic Brake Control Module																																																									
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2011	Cruze	Body	Body Control Module																																																									
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2011	Cruze	Body	Passenger Presence Module																																																									
J	2011	Cruze	Body	Instrument Cluster																																																									
J	2011	Cruze	Body	Trailer Interface Control Module																																																									
J	2011	Cruze	Body	Radio																																																									
J	2011	Cruze	Body	Multimedia Player Interface Module																																																									
J	2011	Cruze	Body	Mobile Telephone Control Module																																																									
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
J	2011	Cruze	Body	Keyless Entry Control Module																																																									
J	2011	Cruze	Body	Parking Assist Control Module																																							V	V	V															
J	2011	Cruze	Body	Steering Column Lock Control Module																																																									
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																									
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																									
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																									
J	2011	Other	Powertrain	Transmission Control Module 5 Speed																																																									
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No																																																									
J	2011	Other	Chassis	Tire Pressure Monitor																																																									
J	2011	Other	Body	Remote Function Actuation																																																									
J	2011	Other	Body	Supplemental Inflatable Restraint																																																									
J	2011	Other	Body	Supplemental Inflatable Restraint																																																									
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2012	Aveo	Powertrain	Fuel Pump Control Module																																																													
J	2012	Aveo	Powertrain	Fuel Injector Control Module																																																													
J	2012	Aveo	Chassis	Electronic Brake Control Module																																																													
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Aveo	Chassis	Electric Power Steering Control Module																																																												
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Aveo	Body	Body Control Module Hatchback																																																												
J	2012	Aveo	Body	Body Control Module Sedan																																																												
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2012	Aveo	Body	Passenger Presence Module																																																												
J	2012	Aveo	Body	Instrument Cluster																																																												
J	2012	Aveo	Body	Radio																																																											
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																			V																																								
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
J	2012	Aveo	Body	Front Seat Heating Control Module																																																											
J	2012	Aveo	Body	Parking Assist Control Module																																							V																			
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																											
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																											
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2012	Cobalt	Chassis	Electronic Brake Control Module																																																												
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																											
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2012	Cobalt	Body	Body Control Module																																																											
J	2012	Cobalt	Body	Passenger Presence Module																																																											
J	2012	Cobalt	Body	Instrument Cluster																																																											
J	2012	Cobalt	Body	Radio																																																										
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																			V																																								
J	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																											
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
J	2012	Cobalt	Body	Front Seat Heating Control Module																																																												
J	2012	Cobalt	Body	Parking Assist Control Module																																							V																				
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																													V																															
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																													V																															
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																												
J	2012	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Cruze	Body	Body Control Module Hatchback																																																												
J	2012	Cruze	Body	Body Control Module Sedan																																																												
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2012	Cruze	Body	Passenger Presence Module																																																												
J	2012	Cruze	Body	Instrument Cluster																																																												
J	2012	Cruze	Body	Trailer Interface Control Module																																																												
J	2012	Cruze	Body	Radio																																																											
J	2012	Cruze	Body	Multimedia Player Interface Module																																																											
J	2012	Cruze	Body	Mobile Telephone Control Module																																																											
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																												
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																												
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																												
J	2012	Cruze	Body	Keyless Entry Control Module																																																												
J	2012	Cruze	Body	Parking Assist Control Module																																							V	V	V																	
J	2012	Cruze	Body	Steering Column Lock Control Module																																																												
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																												
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																												
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																												
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																												
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																												
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																												
J	2012	Sonic (First Gen)	Body	Remote Function Actuation																																																												
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																												
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																												
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module																																																												
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																												
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																											
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																											
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																											
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																											
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																											
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																											
J	2013	Cruze	Chassis	Electronic Brake Control Module																																																											
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2013	Cruze	Body	Body Control Module Hatchback																																																											
J	2013	Cruze	Body	Body Control Module Sedan																																																											
J	2013	Cruze	Body	Body Control Module Station Wagon																																																											
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2013	Cruze	Body	Passenger Presence Module																																																											
J	2013	Cruze	Body	Instrument Cluster																																																											
J	2013	Cruze	Body	Trailer Interface Control Module																																																											
J	2013	Cruze	Body	Radio																																																											
J	2013	Cruze	Body	Digital Radio Receiver Control Module																																																											
J	2013	Cruze	Body	Multimedia Player Interface Module																																																											
J	2013	Cruze	Body	Mobile Telephone Control Module																																																											
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																											
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																											
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																											
J	2013	Cruze	Body	Front Seat Heating Control Module																																																											
J	2013	Cruze	Body	Keyless Entry Control Module																																																											
J	2013	Cruze	Body	Right Side Object Detection Control Module																																																											
J	2013	Cruze	Body	Left Side Object Detection Control Module																																																											
J	2013	Cruze	Body	Parking Assist Control Module																																							V	V	V																		
J	2013	Cruze	Body	Steering Column Lock Control Module																																																											
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																											
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
J	2014	Aveo	Powertrain	Chassis Control Module																																																												
J	2014	Aveo	Powertrain	Fuel Injector Control Module																																																												
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2014	Aveo	Chassis	Power Steering Control Module																																	V																												
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Aveo	Body	Body Control Module Hatchback																																																												
J	2014	Aveo	Body	Body Control Module Sedan																																																												
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Aveo	Body	Instrument Cluster																																																												
J	2014	Aveo	Body	Radio																																																											
J	2014	Aveo	Body	Telematics Communication Interface Control Module																																																												
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Aveo	Body	Front Seat Heating Control Module																																																												
J	2014	Aveo	Body	Keyless Entry Control Module																																																												
J	2014	Aveo	Body	Parking Assist Control Module																																							V																				
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																												
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
J	2014	Cobalt	Chassis	Electronic Brake Control Module																																																												
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Cobalt	Body	Body Control Module																																																											
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Cobalt	Body	Instrument Cluster																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module								V																																																				
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																												
J	2014	Cruze	Powertrain	Fuel Injector Control Module																																																												
J	2014	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2014	Cruze	Chassis	Power Steering Control Module																																																												
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Cruze	Body	Body Control Module Hatchback																																																												
J	2014	Cruze	Body	Body Control Module Sedan																																																												
J	2014	Cruze	Body	Body Control Module Station Wagon																																																												
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Cruze	Body	Passenger Presence Module																																																												
J	2014	Cruze	Body	Instrument Cluster																																																												
J	2014	Cruze	Body	Trailer Interface Control Module																																																												
J	2014	Cruze	Body	Radio																																																											
J	2014	Cruze	Body	Digital Radio Receiver Control Module																																																											
J	2014	Cruze	Body	Multimedia Player Interface Module																																																											
J	2014	Cruze	Body	Mobile Telephone Control Module																																																											
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																											
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																											
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																											
J	2014	Cruze	Body	Front Seat Heating Control Module																																																											
J	2014	Cruze	Body	Keyless Entry Control Module																																																											
J	2014	Cruze	Body	Right Side Object Detection Control Module																																																											
J	2014	Cruze	Body	Left Side Object Detection Control Module																																																											
J	2014	Cruze	Body	Parking Assist Control Module																																							V	V	V																
J	2014	Cruze	Body	Steering Column Lock Control Module																																																											
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module																																																											
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																													
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																													
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																													
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																													
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																													
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																													
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																													
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																													
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																													
J	2015	Aveo	Powertrain	Chassis Control Module																																																													
J	2015	Aveo	Powertrain	Fuel Injector Control Module																																																													
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																													
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																													
J	2015	Aveo	Chassis	Power Steering Control Module																																V																													
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2015	Aveo	Body	Body Control Module Hatchback																																																													
J	2015	Aveo	Body	Body Control Module Sedan																																																													
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2015	Aveo	Body	Instrument Cluster																																																													
J	2015	Aveo	Body	Radio																																																												
J	2015	Aveo	Body	Telematics Communication Interface Control Module																																																													
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																													
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																													
J	2015	Aveo	Body	Front Seat Heating Control Module																																																													
J	2015	Aveo	Body	Keyless Entry Control Module																																																													
J	2015	Aveo	Body	Parking Assist Control Module																																							V																					
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																													
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																													
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																													
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																													
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																													
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																													
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																													
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																													
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																													
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																													
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																													
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																													
J	2015	Cobalt	Chassis	Electronic Brake Control Module																																																													
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2015	Cobalt	Body	Body Control Module																	V																																											
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2015	Cobalt	Body	Instrument Cluster																																																													
J	2015	Cobalt	Body	Radio																																																												
J	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																													
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																													

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2016	Cruze	Body	Right Side Object Detection Control Module																																																													
J	2016	Cruze	Body	Left Side Object Detection Control Module																																																													
J	2016	Cruze	Body	Parking Assist Control Module																																							V	V	V																			
J	2016	Cruze	Body	Steering Column Lock Control Module																																																												
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																												
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module																																																												
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2016	Sonic	Powertrain	Chassis Control Module																																																												
J	2016	Sonic	Powertrain	Fuel Injector Control Module																																																												
J	2016	Sonic	Chassis	Electronic Brake Control Module																																																												
J	2016	Sonic	Chassis	Power Steering Control Module																																	V																											
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Sonic	Body	Body Control Module Hatchback									V																																																		
J	2016	Sonic	Body	Body Control Module Sedan									V																																																		
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Sonic	Body	Passenger Presence Module																																																												
J	2016	Sonic	Body	Instrument Cluster																																																											
J	2016	Sonic	Body	Radio Other																																																											
J	2016	Sonic	Body	Radio (UF7)																																																											
J	2016	Sonic	Body	Radio (UH7)																																																											
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7																																																											
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)																																																												
J	2016	Sonic	Body	Front Seat Heating Control Module																																																													
J	2016	Sonic	Body	Parking Assist Control Module																																							V	V	V																			
J	2016	Sonic	Body	Frontview Camera Module																										V	V																																
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module																																																											
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2016	Spin	Chassis	Electronic Brake Control Module																																																											
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Spin	Body	Body Control Module									V																																																	
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Spin	Body	Instrument Cluster																																																											
J	2016	Spin	Body	Radio																																																											
J	2016	Spin	Body	Telematics Communication Interface Control Module																																																											
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)																																																											
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Spin	Body	Front Seat Heating Control Module																																																											
J	2016	Spin	Body	Parking Assist Control Module																																																											
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																											
K	2006	ALL	Powertrain	Transmission Control Module																																																											
K	2006	ALL	Chassis	Electronic Brake Control Module																																																											
K	2006	ALL	Body	Remote Function Actuation																																																											
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																											
K	2007	ALL	Powertrain	Transmission Control Module																																																											
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module																																																											
K	2007	ALL	Chassis	Teves Electronic Brake Control Module																																																											
K	2007	ALL	Body	Remote Function Actuation																																																											
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																											
K	2008	ALL	Powertrain	Transmission Control Module																																																											
K	2008	ALL	Chassis	Electronic Brake Control Module																																																											
K	2008	ALL	Body	Remote Function Actuation																																																											
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																											
K	2009	ALL	Powertrain	Transmission Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2013	Prisma	Body	Parking Assist Control Module																																						V																			
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																									
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module																																																									
K	2014	Onix	Chassis	Electronic Brake Control Module																																																									
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																									
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2014	Onix	Body	Body Control Module																																	V	V																						
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2014	Onix	Body	Instrument Cluster																																																									
K	2014	Onix	Body	Radio																																																									
K	2014	Onix	Body	Parking Assist Control Module																																						V	V	V																	
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module																																																									
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																									
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																									
K	2014	Prisma	Chassis	Electronic Brake Control Module																																																									
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																									
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2014	Prisma	Body	Body Control Module																																	V	V																						
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2014	Prisma	Body	Instrument Cluster																																																									
K	2014	Prisma	Body	Radio																																																									
K	2014	Prisma	Body	Parking Assist Control Module																																						V	V	V																	
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																									
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module																																																									
K	2015	Onix	Chassis	Electronic Brake Control Module																																																									
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2015	Onix	Body	Body Control Module																V																	V	V																						
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2015	Onix	Body	Instrument Cluster																																																									
K	2015	Onix	Body	Radio																																																									
K	2015	Onix	Body	Parking Assist Control Module																																						V																			
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
L	2004	ALL	Body	ISU																																																												
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																													
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																													
L	2005	ALL	Powertrain	Transmission Control Module																																																													
L	2005	ALL	Chassis	Anti-lock Brake System																																																													
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																													
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																													
L	2005	ALL	Body	ISU																																																												
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																													
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																													
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																													
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																													
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																													
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																													
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																													
L	2006	ALL	Body	ISU																																																												
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																													
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																													
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																													
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																													
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																													
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector																																																													
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																													
L	2007	ALL	Chassis	Electronic Brake Control Module																																																													
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																													
L	2007	ALL	Body	ISU																																																												
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																													
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																													
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																													
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																													
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																													
L	2008	ALL	Chassis	Electronic Brake Control Module																																																													
L	2008	ALL	Body	Supplemental Inflatable Restraint																																																													
L	2008	ALL	Body	ISU																																																												
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																													
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																													
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																													
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																													
L	2009	ALL	Chassis	Electronic Brake Control Module																																																													
L	2009	ALL	Body	Supplemental Inflatable Restraint																																																													
L	2009	ALL	Body	ISU																																																												
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																													
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																													
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																													
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																													
L	2010	ALL	Chassis	Electronic Brake Control Module																																																													
L	2010	ALL	Body	Supplemental Inflatable Restraint																																																													
L	2010	ALL	Body	ISU																																																												
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																													
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																													

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																											
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																											
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																											
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																											
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																											
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																													V																														
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																											
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2011	Cruze	Chassis	Electronic Brake Control Module																																																											
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2011	Cruze	Body	Body Control Module																																																										
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2011	Cruze	Body	Passenger Presence Module																																																											
P	2011	Cruze	Body	Instrument Cluster																																																											
P	2011	Cruze	Body	Trailer Interface Control Module																																																											
P	2011	Cruze	Body	Radio																																																										
P	2011	Cruze	Body	Multimedia Player Interface Module																																																											
P	2011	Cruze	Body	Mobile Telephone Control Module																																																											
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2011	Cruze	Body	Keyless Entry Control Module																																																											
P	2011	Cruze	Body	Parking Assist Control Module																																							V	V	V																	
P	2011	Cruze	Body	Steering Column Lock Control Module																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																											
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
P	2013	Cruze	Body	Trailer Interface Control Module																																																													
P	2013	Cruze	Body	Radio																																																													
P	2013	Cruze	Body	Digital Radio Receiver Control Module																																																													
P	2013	Cruze	Body	Multimedia Player Interface Module																																																													
P	2013	Cruze	Body	Mobile Telephone Control Module																																																													
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																													
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																													
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																													
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																													
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																													
P	2013	Cruze	Body	Front Seat Heating Control Module																																																													
P	2013	Cruze	Body	Keyless Entry Control Module																																																													
P	2013	Cruze	Body	Right Side Object Detection Control Module																																																													
P	2013	Cruze	Body	Left Side Object Detection Control Module																																																													
P	2013	Cruze	Body	Parking Assist Control Module																																								V	V	V																		
P	2013	Cruze	Body	Steering Column Lock Control Module																																																												
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																													
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																													

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																V																													
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2016	Cruze	Powertrain	Fuel Injector Control Module																																																												
P	2016	Cruze	Powertrain	Chassis Control Module																																																												
P	2016	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2016	Cruze	Chassis	Power Steering Control Module																																	V																											
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2016	Cruze	Body	Body Control Module Hatchback									V																																																		
P	2016	Cruze	Body	Body Control Module Sedan									V																																																		
P	2016	Cruze	Body	Body Control Module Station Wagon									V																																																		
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2016	Cruze	Body	Passenger Presence Module																																																												
P	2016	Cruze	Body	Instrument Cluster																																																												
P	2016	Cruze	Body	Trailer Interface Control Module																																																												
P	2016	Cruze	Body	Radio Other																																																											
P	2016	Cruze	Body	Radio (UF7)																																																											
P	2016	Cruze	Body	Multimedia Player Interface Module																																																											
P	2016	Cruze	Body	Mobile Telephone Control Module																																																											
P	2016	Cruze	Body	Telematics Communication Interface Control Module																																																											
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																											
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																											
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																											
P	2016	Cruze	Body	Front Seat Heating Control Module																																																											
P	2016	Cruze	Body	Keyless Entry Control Module																																																											
P	2016	Cruze	Body	Right Side Object Detection Control Module																																																											
P	2016	Cruze	Body	Left Side Object Detection Control Module																																																											
P	2016	Cruze	Body	Parking Assist Control Module																																						V	V	V																	
P	2016	Cruze	Body	Steering Column Lock Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
R	2014	Volt	Chassis	Parking Brake Control Module																																																													
R	2014	Volt	Chassis	Power Steering Control Module																																																													
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module																																																													
R	2014	Volt	Body	Body Control Module																	V																																											
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
R	2014	Volt	Body	Passenger Presence Module																																																													
R	2014	Volt	Body	Instrument Cluster																																																													
R	2014	Volt	Body	Radio																																																												
R	2014	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Volt	Body	HVAC Control Module																																																												
R	2014	Volt	Body	Electric A/C Compressor Control Module																																																												
R	2014	Volt	Body	Coolant Heater Control Module																																																												
R	2014	Volt	Body	Front Seat Heating Control Module																																																												
R	2014	Volt	Body	Keyless Entry Control Module																																																												
R	2014	Volt	Body	Parking Assist Control Module																																							V	V	V																	
R	2014	Volt	Body	Frontview Camera Module																											V																															
R	2014	Volt	Body	Steering Column Lock Control Module																																																												
R	2014	Volt	Body	Battery Charger Control Module																																																												
R	2014	Volt	Body	Battery Energy Control Module						V																																																						
R	2015	Volt	Powertrain	Engine Control Module																																																												
R	2015	Volt	Powertrain	Trasmission Control Module																																																												
R	2015	Volt	Powertrain	Chassis Control Module																																																												
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module			V																																																								
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2				V		V																																																					
R	2015	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2015	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2015	Volt	Chassis	Electronic Brake Control Module																																																											
R	2015	Volt	Chassis	Parking Brake Control Module																																																											
R	2015	Volt	Chassis	Power Steering Control Module																																																											
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2015	Volt	Body	Body Control Module																	V																																										
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Volt	Body	Passenger Presence Module																																																												
R	2015	Volt	Body	Instrument Cluster																																																												
R	2015	Volt	Body	Radio																																																												
R	2015	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2015	Volt	Body	Telematics Communication Interface Control Module																																																												
R	2015	Volt	Body	HVAC Control Module																																																												
R	2015	Volt	Body	Electric A/C Compressor Control Module																																																												
R	2015	Volt	Body	Coolant Heater Control Module																																																												
R	2015	Volt	Body	Front Seat Heating Control Module																																																												
R	2015	Volt	Body	Keyless Entry Control Module																																																												
R	2015	Volt	Body	Parking Assist Control Module																																							V																			
R	2015	Volt	Body	Frontview Camera Module																											V																															
R	2015	Volt	Body	Steering Column Lock Control Module																																																												
R	2015	Volt	Body	Battery Charger Control Module																																																												
R	2015	Volt	Body	Battery Energy Control Module						V																																																						
R	2016	Volt	Powertrain	Engine Control Module																													V																															

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
W	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																														
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																														
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																														
W	2005	ALL	Powertrain	Transmission Control Module																																																														
W	2005	ALL	Body	Body Control Module																																																														
W	2005	ALL	Body	Digital Radio Receiver																																																														
W	2005	ALL	Body	Driver Information Center																																																														
W	2005	ALL	Body	Heating and Air Conditioning																																																														
W	2005	ALL	Body	Instrument Panel Cluster																																																														
W	2005	ALL	Body	Personalization																																																														
W	2005	ALL	Body	Radio																																																														
W	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																														
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																														
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																														
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																														
W	2006	ALL	Powertrain	Transmission Control Module																																																														
W	2006	ALL	Chassis	Anti-lock Brake System																																																														
W	2006	ALL	Body	Digital Radio Receiver																																																														
W	2006	ALL	Body	Radio																																																														
W	2006	ALL	Body	Instrument Panel Cluster																																																														
W	2006	ALL	Body	Seat																																																														
W	2006	ALL	Body	Theft Deterrent Module																																																														
W	2006	ALL	Body	Body Control Module																																																														
W	2006	ALL	Body	HVAC C67 Single																																																														
W	2006	ALL	Body	HVAC CJ3 Dual																																																														
W	2006	ALL	Body	Remote Control Door Lock Receiver																																																														
W	2006	ALL	Body	Supplemental Inflatable Restraint																																																														
W	2006	ALL	Body	Passenger Presence System																																																														
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																														
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																														
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																														
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module																																																														
W	2007	ALL	Powertrain	Transmission Control Module																																																														
W	2007	ALL	Chassis	Electronic Brake Control Module																																																														
W	2007	ALL	Body	Body Control Module																																																														
W	2007	ALL	Body	Digital Radio Receiver																																																														
W	2007	ALL	Body	Heated Seat Module																																																														
W	2007	ALL	Body	HVAC C67 Single																																																														
W	2007	ALL	Body	HVAC CJ3 Dual																																																														
W	2007	ALL	Body	Instrument Panel Cluster																																																														
W	2007	ALL	Body	Passenger Presence System																																																														
W	2007	ALL	Body	Radio																																																														
W	2007	ALL	Body	Supplemental Inflatable Restraint																																																														
W	2007	ALL	Body	Theft Deterrent Module																																																														
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																														
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																														
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module																																																														
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																														
W	2008	ALL	Powertrain	Transmission Control Module																																																														

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
Y	2012	ALL	Body	Folding Top Module																																																														
Y	2012	ALL	Body	Head Up Display																																																														
Y	2012	ALL	Body	HVAC Control Module																																				V																										
Y	2012	ALL	Body	Instrument Panel Cluster																																																													
Y	2012	ALL	Body	Navigation Radio																																																														
Y	2012	ALL	Body	Passenger Door Module																																																													
Y	2012	ALL	Body	Radio																																																													
Y	2012	ALL	Body	Personal Audio Link Module																																																													
Y	2012	ALL	Body	Remote Control Door Lock Receiver																																																													
Y	2012	ALL	Body	Steering Column Lock Module																																																													
Y	2012	ALL	Body	Supplemental Inflatable Restraint																																																													
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																													
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																													
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																													
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																													
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																													
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																													
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																													
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																													
Y	2013	ALL	Chassis	Electronic Brake Control Module																																																														
Y	2013	ALL	Chassis	Electronic Suspension Control																																																														
Y	2013	ALL	Body	Body Control Module																																																														
Y	2013	ALL	Body	CD Changer																																																														
Y	2013	ALL	Body	Digital Radio Receiver																																																														
Y	2013	ALL	Body	Driver Door Module																																																														
Y	2013	ALL	Body	Driver Door Switch																																																														
Y	2013	ALL	Body	Driver Position Module																																																														
Y	2013	ALL	Body	Folding Top Module																																																														
Y	2013	ALL	Body	Head Up Display																																																														
Y	2013	ALL	Body	HVAC Control Module																																				V																										
Y	2013	ALL	Body	Instrument Panel Cluster																																																														
Y	2013	ALL	Body	Navigation Radio																																																														
Y	2013	ALL	Body	Passenger Door Module																																																														
Y	2013	ALL	Body	Radio																																																														
Y	2013	ALL	Body	Personal Audio Link Module																																																														
Y	2013	ALL	Body	Remote Control Door Lock Receiver																																																														
Y	2013	ALL	Body	Steering Column Lock Module																																																														
Y	2013	ALL	Body	Supplemental Inflatable Restraint																																																														
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																														
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																														
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																														
Y	2014	Corvette	Powertrain	Chassis Control Module																																																														
Y	2014	Corvette	Chassis	Electronic Brake Control Module											V	V	V	V	V																																														
Y	2014	Corvette	Chassis	Parking Brake Control Module																																																														
Y	2014	Corvette	Chassis	Power Steering Control Module																																																														
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																														
Y	2014	Corvette	Chassis	Suspension Control Module																																																														
Y	2014	Corvette	Body	Body Control Module Convertible																																																														
Y	2014	Corvette	Body	Body Control Module Coupe																																																														
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
Y	2014	Corvette	Body	Passenger Presence Module																																																														

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
Z	2006	ALL	Body	HVAC Control Module																																				V																							
Z	2006	ALL	Body	Instrument Panel Cluster																																																										
Z	2006	ALL	Body	Radio																																																									
Z	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
Z	2006	ALL	Body	Theft Deterrent Module																																																									
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																									
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																									
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																									
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																									
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																									
Z	2007	ALL	Chassis	Electronic Brake Control Module																																																									
Z	2007	ALL	Chassis	Power Steering Control Module																																																									
Z	2007	ALL	Body	Body Control Module																																																									
Z	2007	ALL	Body	Digital Radio Receiver																																																									
Z	2007	ALL	Body	Disc Player and Video Display																																																									
Z	2007	ALL	Body	HVAC Control Module																																				V																						
Z	2007	ALL	Body	Instrument Panel Cluster																																																									
Z	2007	ALL	Body	Radio																																																									
Z	2007	ALL	Body	Remote Control Door Lock Receiver																																																									
Z	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
Z	2007	ALL	Body	Theft Deterrent Module																																																									
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																									
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																									
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																									
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																									
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																									
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																									
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																									
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
Z	2008	ALL	Chassis	Electronic Brake Control Module																																																									
Z	2008	ALL	Chassis	Power Steering Control Module																																																									
Z	2008	ALL	Body	Body Control Module Classic																																																									
Z	2008	ALL	Body	Body Control Module Malibu																																																									
Z	2008	ALL	Body	Digital Radio Receiver																																																									
Z	2008	ALL	Body	Disc Player and Video Display																																																									
Z	2008	ALL	Body	HVAC Control Module Classic																																				V																						
Z	2008	ALL	Body	HVAC Control Module Malibu																																				V																						
Z	2008	ALL	Body	Instrument Panel Cluster Classic																																																									
Z	2008	ALL	Body	Instrument Panel Cluster Malibu																																																									
Z	2008	ALL	Body	Radio																																																								
Z	2008	ALL	Body	Remote Control Door Lock Receiver																																																									
Z	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
Z	2008	ALL	Body	Theft Deterrent Module																																																									
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																									
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																									
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																									
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump																																																									
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump																																																									
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift																																																									

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																												
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																													V																														
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																													V																														
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
1	2016	Malibu	Powertrain	Fuel Injector Control Module										V	V	V	V	V																																														
1	2016	Malibu	Powertrain	Chassis Control Module																																																												
1	2016	Malibu	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																													
1	2016	Malibu	Chassis	Parking Brake Control Module																																																												
1	2016	Malibu	Chassis	Power Steering Control Module																																																												
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)									V								V																																										
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)									V								V																																										
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2016	Malibu	Body	Passenger Presence Module																																																												
1	2016	Malibu	Body	Instrument Cluster																																																												
1	2016	Malibu	Body	Headlamp Control Module																														V					V																								
1	2016	Malibu	Body	Radio																																																											
1	2016	Malibu	Body	Digital Radio Receiver Control Module																																																											
1	2016	Malibu	Body	Multimedia Player Interface Module																																																											
1	2016	Malibu	Body	Mobile Telephone Control Module																																																											
1	2016	Malibu	Body	Telematics Communication Interface Control Module																																																											
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																											
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																											
1	2016	Malibu	Body	Seat Memory Control Module																																																											
1	2016	Malibu	Body	Front Seat Heating Control Module																																																											
1	2016	Malibu	Body	Rear Seat Heating Control Module																																																											
1	2016	Malibu	Body	Keyless Entry Control Module																																																											
1	2016	Malibu	Body	Left Side Object Detection Control Module																																																											
1	2016	Malibu	Body	Parking Assist Control Module																																																											
1	2016	Malibu	Body	Frontview Camera Module																											V	V																																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2005	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																													V	V																										
A	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																													V	V																										
A	2005	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2005	ALL	Chassis	Power Steering Control Module																																																								
A	2005	ALL	Chassis	Anti-lock Brake System																																																								
A	2005	ALL	Body	Body Control Module																																										V													
A	2005	ALL	Body	Digital Radio Receiver																																																							
A	2005	ALL	Body	Instrument Panel																																																							
A	2005	ALL	Body	Radio																																																							
A	2005	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
A	2006	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																													V	V																										
A	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																													V	V																										
A	2006	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																							
A	2006	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2006	ALL	Chassis	Power Steering Control Module																																																							
A	2006	ALL	Chassis	Anti-lock Brake System																																																							
A	2006	ALL	Body	Body Control Module																																										V													
A	2006	ALL	Body	Digital Radio Receiver																																																							
A	2006	ALL	Body	Instrument Panel																																																							
A	2006	ALL	Body	Radio																																																							
A	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
A	2006	ALL	Body	Theft Deterrent Module																																																							
A	2007	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																													V	V																										
A	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																											V	V	V	V																										
A	2007	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																											V	V	V	V																										
A	2007	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2007	ALL	Chassis	Power Steering Control Module																																																							
A	2007	ALL	Chassis	Electronic Brake Control Module																																																							
A	2007	ALL	Body	Body Control Module																																										V													
A	2007	ALL	Body	Digital Radio Receiver																																																							
A	2007	ALL	Body	Instrument Panel Cluster																																																							
A	2007	ALL	Body	Passenger Presence System																																																							
A	2007	ALL	Body	Personal Audio Link Module																																																							
A	2007	ALL	Body	Radio																																																							
A	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
A	2007	ALL	Body	Theft Deterrent Module																																																							
A	2008	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																											V	V	V	V																										
A	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																											V	V	V	V																										
A	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																											V	V	V	V																										
A	2008	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2008	ALL	Chassis	Power Steering Control Module																																																							
A	2008	ALL	Chassis	Electronic Brake Control Module with VSES																																			V																				
A	2008	ALL	Chassis	Electronic Brake Control Module without VSES																																																							
A	2008	ALL	Body	Body Control Module																																										V													
A	2008	ALL	Body	Digital Radio Receiver																																																							
A	2008	ALL	Body	Instrument Panel Cluster																																																							
A	2008	ALL	Body	Passenger Presence System																																																							
A	2008	ALL	Body	Personal Audio Link Module																																																							
A	2008	ALL	Body	Radio																																																							
A	2008	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
A	2008	ALL	Body	Theft Deterrent Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2009	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																											V	V	V	V																									
A	2009	ALL	Powertrain	(H)2.2L L4 LAP Engine Control Module																											V		V	V																									
A	2009	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V										V																						
A	2009	ALL	Chassis	Power Steering Control Module																																																						
A	2009	ALL	Chassis	Electronic Brake Control Module with VSES																																			V																				
A	2009	ALL	Chassis	Electronic Brake Control Module without VSES																																																					
A	2009	ALL	Body	Body Control Module																																									V												
A	2009	ALL	Body	Digital Radio Receiver																																																					
A	2009	ALL	Body	Instrument Panel Cluster																																																					
A	2009	ALL	Body	Passenger Presence System																																																					
A	2009	ALL	Body	Personal Audio Link Module																																																					
A	2009	ALL	Body	Radio																																																					
A	2009	ALL	Body	Supplemental Inflatable Restraint																																					V																V
A	2009	ALL	Body	Theft Deterrent Module																																																					
A	2010	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																											V	V	V	V																									
A	2010	ALL	Powertrain	(5)2.2L L4 LAP Engine Control Module																											V		V	V																									
A	2010	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V										V																						
A	2010	ALL	Chassis	Power Steering Control Module																																																					
A	2010	ALL	Chassis	Electronic Brake Control Module with VSES																																			V																				
A	2010	ALL	Chassis	Electronic Brake Control Module without VSES																																																					
A	2010	ALL	Body	Body Control Module																																									V												
A	2010	ALL	Body	Digital Radio Receiver																																																					
A	2010	ALL	Body	Driver Information Center																																																					
A	2010	ALL	Body	Instrument Panel Cluster																																																					
A	2010	ALL	Body	Passenger Presence System																																																					
A	2010	ALL	Body	Personal Audio Link Module																																																					
A	2010	ALL	Body	Radio																																																					
A	2010	ALL	Body	Supplemental Inflatable Restraint																																					V																V
A	2010	ALL	Body	Theft Deterrent Module																																																					
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																					
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																					
A	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																					
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																					
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																					
A	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																					
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																					
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																					
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																					
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																					
A	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																					
A	2012	Cobalt	Chassis	Electronic Brake Control Module																																																					
A	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																					
A	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																					
A	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																					
A	2012	Cobalt	Body	Body Control Module																																																					
A	2012	Cobalt	Body	Passenger Presence Module																																																					
A	2012	Cobalt	Body	Instrument Cluster																																																					
A	2012	Cobalt	Body	Radio																																																					
A	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																					
A	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																					
A	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																					

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
A	2012	Cobalt	Body	Front Seat Heating Control Module																																																									
A	2012	Cobalt	Body	Parking Assist Control Module																																																									
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																									
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																									
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																									
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																									
A	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																									
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
A	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																									
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																									
A	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																									
A	2013	Cobalt	Chassis	Electronic Brake Control Module																																																									
A	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2013	Cobalt	Body	Body Control Module																																																									
A	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2013	Cobalt	Body	Instrument Cluster																																																									
A	2013	Cobalt	Body	Radio																																																									
A	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																									
A	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									
A	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
A	2013	Cobalt	Body	Front Seat Heating Control Module																																																									
A	2013	Cobalt	Body	Parking Assist Control Module																																																									
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																									
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																									
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																									
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																									
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																									
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																									
A	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																									
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
A	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																									
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																									
A	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																									
A	2014	Cobalt	Chassis	Electronic Brake Control Module																																																									
A	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2014	Cobalt	Body	Body Control Module																																																									
A	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2014	Cobalt	Body	Instrument Cluster																																																									
A	2014	Cobalt	Body	Radio																																																									
A	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
A	2014	Cobalt	Body	Front Seat Heating Control Module																																																									
A	2014	Cobalt	Body	Parking Assist Control Module																																																									
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																									
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																									
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																									
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																									
A	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																									
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
A	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																									
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																									
A	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																									
A	2015	Cobalt	Chassis	Electronic Brake Control Module																																																									
A	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2015	Cobalt	Body	Body Control Module																																																									
A	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2015	Cobalt	Body	Instrument Cluster																																																									
A	2015	Cobalt	Body	Radio																																																									
A	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																									
A	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									
A	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
A	2015	Cobalt	Body	Front Seat Heating Control Module																																																									
A	2015	Cobalt	Body	Parking Assist Control Module																																																									
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																									
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																									
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																									
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																									
A	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																									
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
A	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																									
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																									
A	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																									
A	2016	Cobalt	Chassis	Electronic Brake Control Module																																																									
A	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2016	Cobalt	Body	Body Control Module																																																									
A	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2016	Cobalt	Body	Instrument Cluster																																																									
A	2016	Cobalt	Body	Radio Other																																																									
A	2016	Cobalt	Body	Radio (IOB)																																																									
A	2016	Cobalt	Body	Radio (UF7)																																																									
A	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
A	2016	Cobalt	Body	Front Seat Heating Control Module																																																									
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																									
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																									
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module																																																									
B	2010	Beat	Powertrain	Transmission Control Module																																																									
B	2010	Beat	Chassis	Electronic Brake Control Module																																																									
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																									
B	2010	Beat	Chassis	Power Steering Control Module																																																									
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module																																																									
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
B	2010	Beat	Body	Instrument Cluster																																																									
B	2010	Beat	Body	Keyless Entry Control Module																																																									
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																									
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																									
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module																																																									
B	2011	Beat	Powertrain	Transmission Control Module																																																									
B	2011	Beat	Chassis	Electronic Brake Control Module																																																									
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																									
B	2011	Beat	Chassis	Electric Power Steering Control Module																																																									
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module																																																									
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
B	2011	Beat	Body	Instrument Cluster																																																									
B	2011	Beat	Body	Keyless Entry Control Module																																																									
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module																																																									
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module																																																									
B	2012	Beat	Powertrain	Transmission Control Module																																																									
B	2012	Beat	Chassis	Electronic Brake Control Module																																																									
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																									
B	2012	Beat	Chassis	Electric Power Steering Control Module																																																									
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module																																																									
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
B	2012	Beat	Body	Instrument Cluster																																																									
B	2012	Beat	Body	Keyless Entry Control Module																																																									
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module																																																									
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module																																																									
B	2013	Beat	Powertrain	Transmission Control Module																																																									
B	2013	Beat	Chassis	Electronic Brake Control Module																																																									
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																									
B	2013	Beat	Chassis	Electric Power Steering Control Module																																																									
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module																																																									
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
B	2013	Beat	Body	Instrument Cluster																																																									
B	2013	Beat	Body	Keyless Entry Control Module																																																									
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module																																																									
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module																																																									
B	2014	Beat	Powertrain	Transmission Control Module																																																									
B	2014	Beat	Powertrain	Fuel Injector Control Module																																																									
B	2014	Beat	Chassis	Electronic Brake Control Module																																																									
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
B	2014	Beat	Chassis	Power Steering Control Module																																																									
B	2014	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2014	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2014	Beat	Body	Instrument Cluster																																																										
B	2014	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2015	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2015	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2015	Beat	Powertrain	Transmission Control Module																																																										
B	2015	Beat	Powertrain	Fuel Injector Control Module																																																										
B	2015	Beat	Chassis	Electronic Brake Control Module																																																										
B	2015	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2015	Beat	Chassis	Power Steering Control Module																																																										
B	2015	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2015	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2015	Beat	Body	Instrument Cluster																																																										
B	2015	Beat	Body	Radio																																																										
B	2015	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2015	Beat	Body	Keyless Entry Control Module																																																										
B	2016	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2016	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2016	Beat	Powertrain	Transmission Control Module																																																										
B	2016	Beat	Chassis	Electronic Brake Control Module																																																										
B	2016	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2016	Beat	Chassis	Power Steering Control Module																																																										
B	2016	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2016	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2016	Beat	Body	Instrument Cluster																																																										
B	2016	Beat	Body	Radio																																																										
B	2016	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2016	Beat	Body	HVAC Control Module																																																										
B	2016	Beat	Body	Keyless Entry Control Module																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																										
B	2016	Cruze	Chassis	Electronic Brake Control Module																																																										
B	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																										
B	2016	Cruze	Chassis	Power Steering Control Module																																																										
B	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2016	Cruze	Body	Body Control Module																																																										
B	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2016	Cruze	Body	Passenger Presence Module																																																										
B	2016	Cruze	Body	Instrument Cluster																																																										
B	2016	Cruze	Body	Radio Controls																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
B	2016	Cruze	Body	HVAC Controls																																																								
B	2016	Cruze	Body	Trailer Interface Control Module																																																								
B	2016	Cruze	Body	Radio Base (IO3 IO7)																																																								
B	2016	Cruze	Body	Radio (IOA)																																																								
B	2016	Cruze	Body	Radio (IOB)																																																								
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																								
B	2016	Cruze	Body	Amplifier																																																								
B	2016	Cruze	Body	Multimedia Player Interface Module																																																								
B	2016	Cruze	Body	Human Machine Interface Control Module																																																								
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																								
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																								
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																								
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																								
B	2016	Cruze	Body	Keyless Entry Control Module																																																								
B	2016	Cruze	Body	Right Side Object Detection Control Module																																																								
B	2016	Cruze	Body	Left Side Object Detection Control Module																																																								
B	2016	Cruze	Body	Parking Assist Control Module																																																								
B	2016	Cruze	Body	Frontview Camera Module																																																								
B	2016	Cruze	Body	Steering Column Lock Control Module																																																								
B	2016	Cruze	Body	Long Range Radar Sensor Module		V																																																						
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
C	2010	Spark	Powertrain	Transmission Control Module																																																								
C	2010	Spark	Chassis	Electronic Brake Control Module																																																								
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
C	2010	Spark	Chassis	Electric Power Steering Control Module																																																								
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2010	Spark	Body	Passenger Presence Module																																																								
C	2010	Spark	Body	Instrument Cluster																																																								
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																								
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																								
C	2011	Spark	Powertrain	Transmission Control Module																																																								
C	2011	Spark	Chassis	Electronic Brake Control Module																																																								
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
C	2011	Spark	Chassis	Electric Power Steering Control Module																																																								
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2011	Spark	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2011	Spark	Body	Instrument Cluster																																																								
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																									
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																									
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																									
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																									
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																									
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																									
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																									
C	2012	Spark	Powertrain	Transmission Control Module																																																									
C	2012	Spark	Chassis	Electronic Brake Control Module																																																									
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
C	2012	Spark	Chassis	Electric Power Steering Control Module																																																									
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2012	Spark	Body	Passenger Presence Module																																																									
C	2012	Spark	Body	Instrument Cluster																																																									
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																									
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																									
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																									
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																									
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																									
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																									
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																									
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																									
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																									
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																									
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																									
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																									
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
C	2013	Spark	Powertrain	Fuel Injector Control Module																																																									
C	2013	Spark	Chassis	Electronic Brake Control Module																																																									
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
C	2013	Spark	Chassis	Power Steering Control Module																																																									
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2013	Spark	Body	Body Control Module																																																									
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2013	Spark	Body	Passenger Presence Module																																																									
C	2013	Spark	Body	Instrument Cluster																																																									
C	2013	Spark	Body	Radio																																																									
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																									
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																									
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																									
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																									
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																									
C	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																									
C	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																									
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																									
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																									
C	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																									
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																									
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
C	2014	Spark	Powertrain	Fuel Injector Control Module																																																									
C	2014	Spark	Chassis	Electronic Brake Control Module																																																									
C	2014	Spark	Chassis	Electronic Brake Control Module																																																									
C	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
C	2014	Spark	Chassis	Power Steering Control Module																																																									
C	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2014	Spark	Body	Body Control Module																																																									
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2014	Spark	Body	Passenger Presence Module																																																									
C	2014	Spark	Body	Instrument Cluster																																																									
C	2014	Spark	Body	Radio																																																									
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																									
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2014	Spark	Body	Keyless Entry Control Module																																																									
C	2014	Spark EV	Powertrain	Engine Control Module																																																									
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																									
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																									
C	2014	Spark EV	Powertrain	Drive Motor Control Module																																																									
C	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																									
C	2014	Spark EV	Chassis	Electronic Brake Control Module																																																									
C	2014	Spark EV	Chassis	Parking Brake Control Module																																																									
C	2014	Spark EV	Chassis	Power Steering Control Module																																																									
C	2014	Spark EV	Body	Body Control Module																																																									
C	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																									
C	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2014	Spark EV	Body	Passenger Presence Module																																																									
C	2014	Spark EV	Body	Instrument Cluster																																																									
C	2014	Spark EV	Body	Radio																																																									
C	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2014	Spark EV	Body	HVAC Control Module																																																									
C	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																									
C	2014	Spark EV	Body	Coolant Heater Control Module																																																									
C	2014	Spark EV	Body	Keyless Entry Control Module																																																									
C	2014	Spark EV	Body	Battery Charger Control Module																																																									
C	2014	Spark EV	Body	DC Charging Control Module																																																									
C	2014	Spark EV	Body	Battery Energy Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																									
C	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Spark	Chassis	Power Steering Control Module																																																										
C	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Spark	Body	Body Control Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Passenger Presence Module																																																										
C	2015	Spark	Body	Instrument Cluster																																																										
C	2015	Spark	Body	Instrument Cluster																																																										
C	2015	Spark	Body	Tire Pressure Indicator Module																																																										
C	2015	Spark	Body	Radio																																																										
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Spark	Body	Keyless Entry Control Module																																																										
C	2015	Spark EV	Powertrain	Engine Control Module																																																										
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
C	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
C	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
C	2015	Spark EV	Chassis	Power Steering Control Module																																																										
C	2015	Spark EV	Body	Body Control Module																																																										
C	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark EV	Body	Passenger Presence Module																																																										
C	2015	Spark EV	Body	Instrument Cluster																																																										
C	2015	Spark EV	Body	Radio																																																										
C	2015	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2015	Spark EV	Body	Coolant Heater Control Module																																																											
C	2015	Spark EV	Body	Keyless Entry Control Module																																																											
C	2015	Spark EV	Body	Battery Charger Control Module																																																											
C	2015	Spark EV	Body	DC Charging Control Module																																																											
C	2015	Spark EV	Body	Battery Energy Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	Fuel Injector Control Module																																																											
C	2016	Spark	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2016	Spark	Chassis	Power Steering Control Module																																																											
C	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Spark	Body	Body Control Module																																																											
C	2016	Spark	Body	Body Control Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Instrument Cluster																																																											
C	2016	Spark	Body	Instrument Cluster																																																											
C	2016	Spark	Body	Radio																																																											
C	2016	Spark	Body	Telematics Communication Interface Control Module																																																											
C	2016	Spark	Body	Keyless Entry Control Module																																																											
C	2016	Spark EV	Powertrain	Engine Control Module																																																											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
C	2016	Spark EV	Powertrain	Drive Motor Control Module																																																											
C	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
C	2016	Spark EV	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark EV	Chassis	Parking Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2016	Spark EV	Chassis	Power Steering Control Module																																																									
C	2016	Spark EV	Body	Body Control Module																																																										
C	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Spark EV	Body	Passenger Presence Module																																																										
C	2016	Spark EV	Body	Instrument Cluster																																																										
C	2016	Spark EV	Body	Radio																																																										
C	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
C	2016	Spark EV	Body	HVAC Control Module																																																										
C	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2016	Spark EV	Body	Coolant Heater Control Module																																																										
C	2016	Spark EV	Body	Keyless Entry Control Module																																																										
C	2016	Spark EV	Body	Frontview Camera Module																																																										
C	2016	Spark EV	Body	Battery Charger Control Module																																																										
C	2016	Spark EV	Body	DC Charging Control Module																																																										
C	2016	Spark EV	Body	Battery Energy Control Module																																																										
D	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2010	Spark	Powertrain	Transmission Control Module																																																										
D	2010	Spark	Chassis	Electronic Brake Control Module																																																										
D	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2010	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2010	Spark	Body	Passenger Presence Module																																																										
D	2010	Spark	Body	Instrument Cluster																																																										
D	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										
D	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
D	2011	Spark	Powertrain	Transmission Control Module																																																										
D	2011	Spark	Chassis	Electronic Brake Control Module																																																										
D	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2011	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2011	Spark	Body	Passenger Presence Module																																																										
D	2011	Spark	Body	Instrument Cluster																																																										
D	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																									
D	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
D	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
D	2012	Spark	Powertrain	Transmission Control Module																																																										
D	2012	Spark	Chassis	Electronic Brake Control Module																																																										
D	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2012	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2012	Spark	Body	Passenger Presence Module																																																										
D	2012	Spark	Body	Instrument Cluster																																																										
D	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										
D	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																										
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
D	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
D	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																										
D	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2013	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2013	Spark	Chassis	Electronic Brake Control Module																																																										
D	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2013	Spark	Chassis	Power Steering Control Module																																																										
D	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2013	Spark	Body	Body Control Module																																																										
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2013	Spark	Body	Passenger Presence Module																																																										
D	2013	Spark	Body	Instrument Cluster																																																										
D	2013	Spark	Body	Radio																																																										
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
D	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
D	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
D	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2014	Spark	Chassis	Electronic Brake Control Module																																																										
D	2014	Spark	Chassis	Electronic Brake Control Module																																																										
D	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2014	Spark	Chassis	Power Steering Control Module																																																										
D	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2014	Spark	Body	Body Control Module																																																										
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	Spark	Body	Passenger Presence Module																																																										
D	2014	Spark	Body	Instrument Cluster																																																										
D	2014	Spark	Body	Radio																																																										
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2014	Spark	Body	Keyless Entry Control Module																																																										
D	2014	Spark EV	Powertrain	Engine Control Module																																																										
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
D	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
D	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
D	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
D	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
D	2014	Spark EV	Chassis	Power Steering Control Module																																																										
D	2014	Spark EV	Body	Body Control Module																																																										
D	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
D	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	Spark EV	Body	Passenger Presence Module																																																										
D	2014	Spark EV	Body	Instrument Cluster																																																										
D	2014	Spark EV	Body	Radio																																																										
D	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2014	Spark EV	Body	HVAC Control Module																																																										
D	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																										
D	2014	Spark EV	Body	Coolant Heater Control Module																																																										
D	2014	Spark EV	Body	Keyless Entry Control Module																																																										
D	2014	Spark EV	Body	Battery Charger Control Module																																																										
D	2014	Spark EV	Body	DC Charging Control Module																																																										
D	2014	Spark EV	Body	Battery Energy Control Module																																																										
D	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
D	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
D	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																									
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2015	Spark	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2015	Spark	Chassis	Power Steering Control Module																																																										
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2015	Spark	Body	Body Control Module																																																										
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark	Body	Passenger Presence Module																																																										
D	2015	Spark	Body	Instrument Cluster																																																										
D	2015	Spark	Body	Instrument Cluster																																																										
D	2015	Spark	Body	Tire Pressure Indicator Module																																																										
D	2015	Spark	Body	Radio																																																										
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2015	Spark	Body	Keyless Entry Control Module																																																										
D	2015	Spark EV	Powertrain	Engine Control Module																																																										
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
D	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
D	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
D	2015	Spark EV	Chassis	Power Steering Control Module																																																										
D	2015	Spark EV	Body	Body Control Module																																																										
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark EV	Body	Passenger Presence Module																																																										
D	2015	Spark EV	Body	Instrument Cluster																																																										
D	2015	Spark EV	Body	Radio																																																										
D	2015	Spark EV	Body	HVAC Control Module																																																										
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
D	2015	Spark EV	Body	Coolant Heater Control Module																																																										
D	2015	Spark EV	Body	Keyless Entry Control Module																																																										
D	2015	Spark EV	Body	Battery Charger Control Module																																																										
D	2015	Spark EV	Body	DC Charging Control Module																																																										
D	2015	Spark EV	Body	Battery Energy Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																									
D	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2016	Spark	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2016	Spark	Chassis	Power Steering Control Module																																																										
D	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2016	Spark	Body	Body Control Module																																																									
D	2016	Spark	Body	Body Control Module																																																									
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark	Body	Instrument Cluster																																																										
D	2016	Spark	Body	Instrument Cluster																																																										
D	2016	Spark	Body	Radio																																																										
D	2016	Spark	Body	Telematics Communication Interface Control Module																																																										
D	2016	Spark	Body	Keyless Entry Control Module																																																										
D	2016	Spark EV	Powertrain	Engine Control Module																																																										
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
D	2016	Spark EV	Powertrain	Drive Motor Control Module																																																										
D	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
D	2016	Spark EV	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark EV	Chassis	Parking Brake Control Module																																																										
D	2016	Spark EV	Chassis	Power Steering Control Module																																																										
D	2016	Spark EV	Body	Body Control Module																																																										
D	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
D	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark EV	Body	Passenger Presence Module																																																										
D	2016	Spark EV	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2016	Spark EV	Body	Radio																																																								
D	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																								
D	2016	Spark EV	Body	HVAC Control Module																																																								
D	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																								
D	2016	Spark EV	Body	Coolant Heater Control Module																																																								
D	2016	Spark EV	Body	Keyless Entry Control Module																																																								
D	2016	Spark EV	Body	Frontview Camera Module																																																								
D	2016	Spark EV	Body	Battery Charger Control Module																																																								
D	2016	Spark EV	Body	DC Charging Control Module																																																								
D	2016	Spark EV	Body	Battery Energy Control Module																																																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Automatic Transmission																																																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Manual Transmission																																																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Transmission Control Module																																																								
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																								
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2010	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																								
F	2010	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																								
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																								
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2010	Camaro	Chassis	Electronic Brake Control Module																																																								
F	2010	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																								
F	2010	Camaro	Chassis	Power Steering Control Module																																																								
F	2010	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2010	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
F	2010	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
F	2010	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2010	Camaro	Body	Passenger Presence Module																																																								
F	2010	Camaro	Body	Instrument Cluster																																																								
F	2010	Camaro	Body	Auxiliary Gage Module																																																								
F	2010	Camaro	Body	Radio																																																								
F	2010	Camaro	Body	Multimedia Player Interface Module																																																								
F	2010	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																								
F	2010	Camaro	Body	Mobile Telephone Control Module																																																								
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																								
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2010	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																								
F	2010	Camaro	Body	Front Seat Heating Control Module																																																								
F	2010	Camaro	Body	Folding Top Control Module																																																								
F	2010	Camaro	Body	Parking Assist Control Module																																																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Automatic Transmission																																																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Manual Transmission																																																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																								
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2011	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																								
F	2011	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																								
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																									
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																										
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2011	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2011	Camaro	Chassis	Power Steering Control Module																																																										
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2011	Camaro	Body	Passenger Presence Module																																																										
F	2011	Camaro	Body	Instrument Cluster																																																										
F	2011	Camaro	Body	Head-Up Display Module																																																										
F	2011	Camaro	Body	Auxiliary Gage Module																																																										
F	2011	Camaro	Body	Headlamp Control Module																																																										
F	2011	Camaro	Body	Radio																																																										
F	2011	Camaro	Body	Multimedia Player Interface Module																																																										
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																										
F	2011	Camaro	Body	Mobile Telephone Control Module																																																										
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																										
F	2011	Camaro	Body	Front Seat Heating Control Module																																																										
F	2011	Camaro	Body	Folding Top Control Module																																																										
F	2011	Camaro	Body	Parking Assist Control Module																																																										
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																										
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																										
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																										
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module																																																										
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																										
F	2012	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2012	Camaro	Chassis	Power Steering Control Module																																																										
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2012	Camaro	Chassis	Suspension Control Module																																																										
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2012	Camaro	Body	Passenger Presence Module																																																										
F	2012	Camaro	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
F	2012	Camaro	Body	Head-Up Display Module																																																									
F	2012	Camaro	Body	Auxiliary Gage Module																																																										
F	2012	Camaro	Body	Headlamp Control Module																																																										
F	2012	Camaro	Body	Radio																																																										
F	2012	Camaro	Body	Multimedia Player Interface Module																																																										
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																										
F	2012	Camaro	Body	Mobile Telephone Control Module																																																										
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																										
F	2012	Camaro	Body	Front Seat Heating Control Module																																																										
F	2012	Camaro	Body	Folding Top Control Module																																																										
F	2012	Camaro	Body	Parking Assist Control Module																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																										
F	2013	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2013	Camaro	Chassis	Power Steering Control Module																																																										
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2013	Camaro	Chassis	Suspension Control Module																																																										
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2013	Camaro	Body	Passenger Presence Module																																																										
F	2013	Camaro	Body	Instrument Cluster																																																										
F	2013	Camaro	Body	Head-Up Display Module																																																										
F	2013	Camaro	Body	Auxiliary Gage Module																																																										
F	2013	Camaro	Body	Headlamp Control Module																																																										
F	2013	Camaro	Body	Radio																																																										
F	2013	Camaro	Body	Multimedia Player Interface Module																																																										
F	2013	Camaro	Body	Mobile Telephone Control Module																																																										
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
F	2013	Camaro	Body	HVAC Control Module																																																									
F	2013	Camaro	Body	Front Seat Heating Control Module																																																										
F	2013	Camaro	Body	Folding Top Control Module																																																										
F	2013	Camaro	Body	Parking Assist Control Module																																																										
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																										
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																										
F	2014	Camaro	Powertrain	Transmission Control Module																																																										
F	2014	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2014	Camaro	Chassis	Parking Brake Control Module																																																										
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2014	Camaro	Chassis	Power Steering Control Module																																																										
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2014	Camaro	Chassis	Suspension Control Module																																																										
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2014	Camaro	Body	Passenger Presence Module																																																										
F	2014	Camaro	Body	Instrument Cluster																																																										
F	2014	Camaro	Body	Head-Up Display Module																																																										
F	2014	Camaro	Body	Auxiliary Gage Module																																																										
F	2014	Camaro	Body	Headlamp Control Module																																																										
F	2014	Camaro	Body	Radio																																																										
F	2014	Camaro	Body	Mobile Telephone Control Module																																																										
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2014	Camaro	Body	HVAC Control Module																																																										
F	2014	Camaro	Body	Front Seat Heating Control Module																																																										
F	2014	Camaro	Body	Folding Top Control Module																																																										
F	2014	Camaro	Body	Parking Assist Control Module																																																										
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module																																																										
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2014	SS	Powertrain	Chassis Control Module																																																										
F	2014	SS	Chassis	Electronic Brake Control Module																																																										
F	2014	SS	Chassis	Parking Brake Control Module																																																										
F	2014	SS	Chassis	Power Steering Control Module																																																										
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2014	SS	Body	Body Control Module																																																										
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2014	SS	Body	Passenger Presence Module																																																										
F	2014	SS	Body	Instrument Cluster																																																										
F	2014	SS	Body	Head-Up Display Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
F	2014	SS	Body	Radio Control																																																							
F	2014	SS	Body	HVAC Control																																																						
F	2014	SS	Body	Headlamp Control Module																																																						
F	2014	SS	Body	Trailer Interface Control Module																																																						
F	2014	SS	Body	Radio																																																						
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9																																																						
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10																																																						
F	2014	SS	Body	HVAC Control Module																																																						
F	2014	SS	Body	Seat Memory Control Module - Driver																																																						
F	2014	SS	Body	Keyless Entry Control Module																																																						
F	2014	SS	Body	Right Side Object Detection Control Module																																																						
F	2014	SS	Body	Left Side Object Detection Control Module																																																						
F	2014	SS	Body	Parking Assist Control Module																																																						
F	2014	SS	Body	Frontview Camera Module																																																						
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																						
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																						
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																						
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																						
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																						
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																						
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																						
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																						
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																						
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																						
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																						
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																						
F	2015	Camaro	Powertrain	Transmission Control Module																																																						
F	2015	Camaro	Chassis	Electronic Brake Control Module																																																						
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																						
F	2015	Camaro	Chassis	Power Steering Control Module																																																						
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																						
F	2015	Camaro	Chassis	Suspension Control Module																																																						
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																						
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																						
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
F	2015	Camaro	Body	Passenger Presence Module																																																						
F	2015	Camaro	Body	Instrument Cluster																																																						
F	2015	Camaro	Body	Head-Up Display Module																																																						
F	2015	Camaro	Body	Auxiliary Gage Module																																																						
F	2015	Camaro	Body	Headlamp Control Module																																																						
F	2015	Camaro	Body	Radio																																																						
F	2015	Camaro	Body	Mobile Telephone Control Module																																																						
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6																																																						
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																						
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																						
F	2015	Camaro	Body	HVAC Control Module																																																						
F	2015	Camaro	Body	Front Seat Heating Control Module																																																						
F	2015	Camaro	Body	Folding Top Control Module																																																						
F	2015	Camaro	Body	Parking Assist Control Module																																																						
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																						
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																									
F	2015	SS	Powertrain	Fuel Injector Control Module																																																										
F	2015	SS	Powertrain	Chassis Control Module																																																										
F	2015	SS	Chassis	Electronic Brake Control Module																																																										
F	2015	SS	Chassis	Parking Brake Control Module																																																										
F	2015	SS	Chassis	Power Steering Control Module																																																										
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2015	SS	Chassis	Suspension Control Module																																																										
F	2015	SS	Body	Body Control Module																																																										
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2015	SS	Body	Passenger Presence Module																																																										
F	2015	SS	Body	Instrument Cluster																																																										
F	2015	SS	Body	Head-Up Display Module																																																										
F	2015	SS	Body	Radio Control																																																										
F	2015	SS	Body	HVAC Control																																																										
F	2015	SS	Body	Headlamp Control Module																																																										
F	2015	SS	Body	Trailer Interface Control Module																																																										
F	2015	SS	Body	Radio																																																										
F	2015	SS	Body	Telematics Communication Interface Control Module																																																										
F	2015	SS	Body	HVAC Control Module																																																										
F	2015	SS	Body	Seat Memory Control Module - Driver																																																										
F	2015	SS	Body	Keyless Entry Control Module																																																										
F	2015	SS	Body	Right Side Object Detection Control Module																																																										
F	2015	SS	Body	Left Side Object Detection Control Module																																																										
F	2015	SS	Body	Parking Assist Control Module																																																										
F	2015	SS	Body	Frontview Camera Module																																																										
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																										
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																										
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																										
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission							V																																																		
F	2016	Camaro	Powertrain	Transmission Control Module																																																										
F	2016	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2016	Camaro	Chassis	Parking Brake Control Module																																																										
F	2016	Camaro	Chassis	Power Steering Control Module																																																										
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2016	Camaro	Chassis	Suspension Control Module																																																										
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2016	Camaro	Body	Serial Data Gateway Module																																																										
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2016	Camaro	Body	Passenger Presence Module																																																										
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																										
F	2016	Camaro	Body	Head-Up Display Module																																																										
F	2016	Camaro	Body	Auxiliary Gage Module																																																										
F	2016	Camaro	Body	Radio Controls																																																										
F	2016	Camaro	Body	HVAC Controls																																																										
F	2016	Camaro	Body	Vehicle Performance Data Recorder																																																										
F	2016	Camaro	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
F	2016	Camaro	Body	Amplifier																																																								
F	2016	Camaro	Body	Media Disc Player																																																								
F	2016	Camaro	Body	Human Machine Interface Control Module																																																								
F	2016	Camaro	Body	Navigation Control Module																																																								
F	2016	Camaro	Body	Mobile Telephone Control Module																																																								
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																								
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)																																																								
F	2016	Camaro	Body	Seat Memory Control Module - Driver																																																								
F	2016	Camaro	Body	Folding Top Control Module																																																								
F	2016	Camaro	Body	Keyless Entry Control Module																																																								
F	2016	Camaro	Body	Right Side Object Detection Control Module																																																								
F	2016	Camaro	Body	Left Side Object Detection Control Module																																																								
F	2016	Camaro	Body	Parking Assist Control Module																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2016	SS	Powertrain	Fuel Injector Control Module																																																								
F	2016	SS	Chassis	Electronic Brake Control Module																																																								
F	2016	SS	Chassis	Parking Brake Control Module																																																								
F	2016	SS	Chassis	Power Steering Control Module																																																								
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2016	SS	Chassis	Suspension Control Module																																																								
F	2016	SS	Body	Body Control Module																																																								
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2016	SS	Body	Passenger Presence Module																																																								
F	2016	SS	Body	Instrument Cluster																																																								
F	2016	SS	Body	Head-Up Display Module																																																								
F	2016	SS	Body	Radio Control																																																								
F	2016	SS	Body	HVAC Control																																																								
F	2016	SS	Body	Trailer Interface Control Module																																																								
F	2016	SS	Body	Radio																																																								
F	2016	SS	Body	Telematics Communication Interface Control Module																																																								
F	2016	SS	Body	HVAC Control Module																																																								
F	2016	SS	Body	Seat Memory Control Module - Driver																																																								
F	2016	SS	Body	Keyless Entry Control Module																																																								
F	2016	SS	Body	Right Side Object Detection Control Module																																																								
F	2016	SS	Body	Left Side Object Detection Control Module																																																								
F	2016	SS	Body	Parking Assist Control Module																																																								
F	2016	SS	Body	Frontview Camera Module																																																								
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
G	2016	Malibu	Powertrain	Fuel Injector Control Module																																																								
G	2016	Malibu	Powertrain	Chassis Control Module																																																								
G	2016	Malibu	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2016	Malibu	Chassis	Parking Brake Control Module																																																									
G	2016	Malibu	Chassis	Power Steering Control Module																																																										
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2016	Malibu	Body	Passenger Presence Module																																																										
G	2016	Malibu	Body	Instrument Cluster																																																										
G	2016	Malibu	Body	Headlamp Control Module																																																										
G	2016	Malibu	Body	Radio																																																										
G	2016	Malibu	Body	Digital Radio Receiver Control Module																																																										
G	2016	Malibu	Body	Multimedia Player Interface Module																																																										
G	2016	Malibu	Body	Mobile Telephone Control Module																																																										
G	2016	Malibu	Body	Telematics Communication Interface Control Module																																																										
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
G	2016	Malibu	Body	Seat Memory Control Module																																																										
G	2016	Malibu	Body	Front Seat Heating Control Module																																																										
G	2016	Malibu	Body	Rear Seat Heating Control Module																																																										
G	2016	Malibu	Body	Keyless Entry Control Module																																																										
G	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
G	2016	Malibu	Body	Parking Assist Control Module																																																										
G	2016	Malibu	Body	Frontview Camera Module																																																										
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
H	2010	Sail	Powertrain	Transmission Control Module																																																										
H	2010	Sail	Chassis	Electronic Brake Control Module																																																										
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
H	2011	Sail	Powertrain	Transmission Control Module																																																										
H	2011	Sail	Chassis	Electronic Brake Control Module																																																										
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	Transmission Control Module																																																										
H	2012	Sail	Chassis	Electronic Brake Control Module																																																										
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
H	2013	Sail	Powertrain	Transmission Control Module																																																								
H	2013	Sail	Chassis	Electronic Brake Control Module																																																								
H	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
H	2014	Sail	Powertrain	Transmission Control Module																																																								
H	2014	Sail	Chassis	Electronic Brake Control Module																																																								
H	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																								
H	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																								
H	2015	Sail	Chassis	Electronic Brake Control Module																																																								
H	2015	Sail	Chassis	Power Steering Control Module																																																								
H	2015	Sail	Body	Body Control Module																																																								
H	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2015	Sail	Body	Radio/HVAC Control																																																								
H	2015	Sail	Body	HVAC Control Module																																																								
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																								
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																								
H	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																								
H	2016	Sail	Chassis	Electronic Brake Control Module																																																								
H	2016	Sail	Chassis	Power Steering Control Module																																																								
H	2016	Sail	Body	Body Control Module																																																								
H	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2016	Sail	Body	Radio/HVAC Control																																																								
H	2016	Sail	Body	Radio																																																								
H	2016	Sail	Body	HVAC Control Module																																																								
J	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																									
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																									
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																											V			V																										
J	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																											V			V																										
J	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																											V			V																										
J	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																										
J	2004	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																								
J	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																										V																														
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																								
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																								
J	2004	Optra	Body	Remote Function Actuation																																																								
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module													V	V	V																																									
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																V	V	V		V	V	V	V		V																															
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel													V	V	V																																									
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel Transmission Control Module																V	V	V		V	V	V	V		V																															
J	2004	Cavalier	Chassis	Anti-lock Brake System																																																								
J	2004	Cavalier	Body	Body Control Module																																																								
J	2004	Cavalier	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2004	Cavalier	Body	Instrument Panel Cluster																																						V																	
J	2004	Cavalier	Body	Radio																																																V						V
J	2004	Cavalier	Body	Supplemental Inflatable Restraint																																					V																	
J	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																							
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V																																								
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																										V			V																									
J	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																										V			V																									
J	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																										V			V																									
J	2005	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																						
J	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																										V																													
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																						
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																						
J	2005	Optra	Body	Remote Function Actuation																																																						
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module													V	V	V																																							
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																V	V	V		V	V	V	V		V																													
J	2005	Cavalier	Chassis	Anti-lock Brake System																																																						
J	2005	Cavalier	Body	Body Control Module																																																						
J	2005	Cavalier	Body	Digital Radio Receiver																																																						
J	2005	Cavalier	Body	Instrument Panel Cluster																																						V																	
J	2005	Cavalier	Body	Radio																																																V						V
J	2005	Cavalier	Body	Supplemental Inflatable Restraint																																					V																		V
J	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																							
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																							
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																										V			V																									
J	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																										V			V																									
J	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																										V			V																									
J	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																										V			V																									
J	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																										V			V																									
J	2006	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																						
J	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																										V																													
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																					
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																						
J	2006	ALL	Body	Remote Function Actuation																																																						
J	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																	
J	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																							
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																							
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																										V			V																									
J	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																										V			V																									
J	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																										V			V																									
J	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																										V			V																									
J	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																										V		V																									
J	2007	ALL	Powertrain	4 Speed Automatic																																																					
J	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																										V																													
J	2007	ALL	Powertrain	Transmission Control Module 5 Speed																										V																													
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																					
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																					
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																					
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																					
J	2007	ALL	Chassis	Tire Pressure Monitor																																																					
J	2007	ALL	Body	Remote Function Actuation																																																					
J	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																										
J	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module													V	V	V																																										
J	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																										
J	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																											V			V																												
J	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																												
J	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																											V		V																												
J	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																												
J	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																											V		V																												
J	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																									
J	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
J	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																										V																																
J	2008	ALL	Powertrain	Transmission Control Module 5 Speed																										V																																
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																									
J	2008	ALL	Chassis	Tire Pressure Monitor																																																									
J	2008	ALL	Body	Remote Function Actuation																																																									
J	2008	ALL	Body	Supplemental Inflatable Restraint																																																	V								
J	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																										
J	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module													V	V	V																																										
J	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																										
J	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																											V			V																												
J	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																												
J	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																											V		V																												
J	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																												
J	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																									
J	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
J	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																										V																																
J	2009	ALL	Powertrain	Transmission Control Module 5 Speed																										V																																
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																									
J	2009	ALL	Chassis	Tire Pressure Monitor																																																									
J	2009	ALL	Body	Remote Function Actuation																																																									
J	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																									
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																									
J	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																									
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																									
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																									
J	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																									
J	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																									
J	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																									
J	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																									
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																									
J	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																									
J	2010	Cruze	Chassis	Electronic Brake Control Module																																																									
J	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2010	Cruze	Body	Body Control Module																																																									
J	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2010	Cruze	Body	Passenger Presence Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2010	Cruze	Body	Instrument Cluster																																																								
J	2010	Cruze	Body	Trailer Interface Control Module																																																								
J	2010	Cruze	Body	Radio																																																								
J	2010	Cruze	Body	Multimedia Player Interface Module																																																								
J	2010	Cruze	Body	Mobile Telephone Control Module																																																								
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																								
J	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																								
J	2010	Cruze	Body	Keyless Entry Control Module																																																								
J	2010	Cruze	Body	Parking Assist Control Module																																																								
J	2010	Cruze	Body	Steering Column Lock Control Module																																																								
J	2010	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module												V	V	V																																										
J	2010	Other	Powertrain	(6)1.6L L4 LXT Engine Control Module												V	V	V																																										
J	2010	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																										
J	2010	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																											V		V																											
J	2010	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																										
J	2010	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2010	Other	Powertrain	MFA Transmission Control Module 4 Speed																										V																														
J	2010	Other	Powertrain	Transmission Control Module 5 Speed																										V																														
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control No																																																								
J	2010	Other	Chassis	Tire Pressure Monitor																																																								
J	2010	Other	Body	Remote Function Actuation																																																								
J	2010	Other	Body	Supplemental Inflatable Restraint																																																								
J	2010	Other	Body	Supplemental Inflatable Restraint																																																								
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																								
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																								
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
J	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																								
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																								
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																								
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																								
J	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																								
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
J	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																								
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																								
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																								
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																								
J	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																								
J	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																										
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2011	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2011	Cruze	Body	Body Control Module																																																										
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2011	Cruze	Body	Passenger Presence Module																																																										
J	2011	Cruze	Body	Instrument Cluster																																																										
J	2011	Cruze	Body	Trailer Interface Control Module																																																										
J	2011	Cruze	Body	Radio																																																										
J	2011	Cruze	Body	Multimedia Player Interface Module																																																										
J	2011	Cruze	Body	Mobile Telephone Control Module																																																										
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
J	2011	Cruze	Body	Keyless Entry Control Module																																																										
J	2011	Cruze	Body	Parking Assist Control Module																																																										
J	2011	Cruze	Body	Steering Column Lock Control Module																																																										
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																										
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module													V	V	V																																										
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																												
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																											V		V																												
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																												
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed																										V																																
J	2011	Other	Powertrain	Transmission Control Module 5 Speed																										V																																
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2011	Other	Chassis	Tire Pressure Monitor																																																										
J	2011	Other	Body	Remote Function Actuation																																																										
J	2011	Other	Body	Supplemental Inflatable Restraint																																																										
J	2011	Other	Body	Supplemental Inflatable Restraint																																																										
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																											
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2012	Aveo	Powertrain	Fuel Pump Control Module																																																												
J	2012	Aveo	Powertrain	Fuel Injector Control Module																																																												
J	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Aveo	Chassis	Electric Power Steering Control Module																																																												
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Aveo	Body	Body Control Module Hatchback																																																												
J	2012	Aveo	Body	Body Control Module Sedan																																																												
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2012	Aveo	Body	Passenger Presence Module																																																												
J	2012	Aveo	Body	Instrument Cluster																																																												
J	2012	Aveo	Body	Radio																																																											
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																												
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
J	2012	Aveo	Body	Front Seat Heating Control Module																																																												
J	2012	Aveo	Body	Parking Assist Control Module																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																												
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2012	Cobalt	Chassis	Electronic Brake Control Module																																																												
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																												
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Cobalt	Body	Body Control Module																																																												
J	2012	Cobalt	Body	Passenger Presence Module																																																												
J	2012	Cobalt	Body	Instrument Cluster																																																												
J	2012	Cobalt	Body	Radio																																																											
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																												
J	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																												
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2012	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2012	Cobalt	Body	Parking Assist Control Module																																																										
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																										
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																										
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																										
J	2012	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2012	Cruze	Body	Body Control Module Hatchback																																																										
J	2012	Cruze	Body	Body Control Module Sedan																																																										
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2012	Cruze	Body	Passenger Presence Module																																																										
J	2012	Cruze	Body	Instrument Cluster																																																										
J	2012	Cruze	Body	Trailer Interface Control Module																																																										
J	2012	Cruze	Body	Radio																																																										
J	2012	Cruze	Body	Multimedia Player Interface Module																																																										
J	2012	Cruze	Body	Mobile Telephone Control Module																																																										
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																								
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																								
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																								
J	2012	Cruze	Body	Keyless Entry Control Module																																																								
J	2012	Cruze	Body	Parking Assist Control Module																																																								
J	2012	Cruze	Body	Steering Column Lock Control Module																																																								
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																									
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module													V	V	V																																									
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																										
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																											V		V																											
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																										V																														
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																										V																														
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																								
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																								
J	2012	Sonic (First Gen)	Body	Remote Function Actuation																																																								
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																								
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																								
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																								
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module Chassis Expansion CAN BUS																																																								
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module High Speed CAN Bus																																																								
J	2012	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																								
J	2012	Sonic (Second Gen)	Body	Body Control Module Sedan																																																								
J	2012	Sonic (Second Gen)	Body	Passenger Presence Module																																																								
J	2012	Sonic (Second Gen)	Body	Instrument Cluster																																																								
J	2012	Sonic (Second Gen)	Body	Radio																																																								
J	2012	Sonic (Second Gen)	Body	Telematic Vehicle Localization and Immobilization Control Module																																																								
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																								
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																								
J	2012	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																								
J	2012	Sonic (Second Gen)	Body	Parking Assist Control Module																																																								
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
J	2013	Aveo	Powertrain	Fuel Pump Control Module																																																								
J	2013	Aveo	Powertrain	Fuel Injector Control Module																																																								
J	2013	Aveo	Chassis	Electronic Brake Control Module																																																								
J	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Aveo	Chassis	Electric Power Steering Control Module																																																								
J	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2013	Aveo	Body	Body Control Module Hatchback																																																								
J	2013	Aveo	Body	Body Control Module Sedan																																																								
J	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2013	Aveo	Body	Passenger Presence Module																																																								
J	2013	Aveo	Body	Instrument Cluster																																																								
J	2013	Aveo	Body	Radio																																																								
J	2013	Aveo	Body	Telematics Communication Interface Control Module																																																								
J	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
J	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								
J	2013	Aveo	Body	Front Seat Heating Control Module																																																								
J	2013	Aveo	Body	Parking Assist Control Module																																																								
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2013	Cobalt	Chassis	Electronic Brake Control Module																																																											
J	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2013	Cobalt	Body	Body Control Module																																																											
J	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2013	Cobalt	Body	Instrument Cluster																																																											
J	2013	Cobalt	Body	Radio																																																										
J	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																											
J	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											
J	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
J	2013	Cobalt	Body	Front Seat Heating Control Module																																																											
J	2013	Cobalt	Body	Parking Assist Control Module																																																											
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2013	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Cruze	Body	Body Control Module Hatchback																																																										
J	2013	Cruze	Body	Body Control Module Sedan																																																										
J	2013	Cruze	Body	Body Control Module Station Wagon																																																										
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Cruze	Body	Passenger Presence Module																																																										
J	2013	Cruze	Body	Instrument Cluster																																																										
J	2013	Cruze	Body	Trailer Interface Control Module																																																										
J	2013	Cruze	Body	Radio																																																										
J	2013	Cruze	Body	Digital Radio Receiver Control Module																																																										
J	2013	Cruze	Body	Multimedia Player Interface Module																																																										
J	2013	Cruze	Body	Mobile Telephone Control Module																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
J	2013	Cruze	Body	Front Seat Heating Control Module																																																										
J	2013	Cruze	Body	Keyless Entry Control Module																																																										
J	2013	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Body	Steering Column Lock Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																									
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module													V	V	V																																									
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																											
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																											V		V																												
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																										V																																
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																										V																																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2013	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																										
J	2013	Sonic (First Gen)	Body	Remote Function Actuation																																																										
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																										
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																										
J	2013	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																										
J	2013	Sonic (Second Gen)	Body	Body Control Module Sedan																																																										
J	2013	Sonic (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Sonic (Second Gen)	Body	Passenger Presence Module																																																										
J	2013	Sonic (Second Gen)	Body	Instrument Cluster																																																										
J	2013	Sonic (Second Gen)	Body	Radio																																																										
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																									
J	2013	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																										
J	2013	Sonic (Second Gen)	Body	Parking Assist Control Module																																																										
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2013	Spin	Chassis	Electronic Brake Control Module																																																										
J	2013	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Spin	Body	Body Control Module																																																										
J	2013	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Spin	Body	Instrument Cluster																																																										
J	2013	Spin	Body	Radio																																																										
J	2013	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Spin	Body	Parking Assist Control Module																																																										
J	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
J	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	Chassis Control Module																																																										
J	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Aveo	Chassis	Power Steering Control Module																																																										
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Aveo	Body	Body Control Module Hatchback																																																										
J	2014	Aveo	Body	Body Control Module Sedan																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Instrument Cluster																																																										
J	2014	Aveo	Body	Radio																																																										
J	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Aveo	Body	Front Seat Heating Control Module																																																										
J	2014	Aveo	Body	Keyless Entry Control Module																																																										
J	2014	Aveo	Body	Parking Assist Control Module																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2014	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Cobalt	Body	Body Control Module																																																										
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Cobalt	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2014	Cobalt	Body	Radio																																																									
J	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									
J	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
J	2014	Cobalt	Body	Front Seat Heating Control Module																																																									
J	2014	Cobalt	Body	Parking Assist Control Module																																																									
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																									
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																									
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																									
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																									
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																									
J	2014	Cruze	Powertrain	Fuel Injector Control Module																																																									
J	2014	Cruze	Chassis	Electronic Brake Control Module																																																									
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2014	Cruze	Chassis	Power Steering Control Module																																																									
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2014	Cruze	Body	Body Control Module Hatchback																																																									
J	2014	Cruze	Body	Body Control Module Sedan																																																									
J	2014	Cruze	Body	Body Control Module Station Wagon																																																									
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2014	Cruze	Body	Passenger Presence Module																																																									
J	2014	Cruze	Body	Instrument Cluster																																																									
J	2014	Cruze	Body	Trailer Interface Control Module																																																									
J	2014	Cruze	Body	Radio																																																									
J	2014	Cruze	Body	Digital Radio Receiver Control Module																																																									
J	2014	Cruze	Body	Multimedia Player Interface Module																																																									
J	2014	Cruze	Body	Mobile Telephone Control Module																																																									
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																									
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																									
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																									
J	2014	Cruze	Body	Front Seat Heating Control Module																																																									
J	2014	Cruze	Body	Keyless Entry Control Module																																																									
J	2014	Cruze	Body	Right Side Object Detection Control Module																																																									
J	2014	Cruze	Body	Left Side Object Detection Control Module																																																									
J	2014	Cruze	Body	Parking Assist Control Module																																																									
J	2014	Cruze	Body	Steering Column Lock Control Module																																																									
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module																																																									
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																									
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																									
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																									
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2014	Sonic	Powertrain	1.4L LDD Chassis Control Module																																																								
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.4L LUJ Chassis Control Module																																																								
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2014	Sonic	Powertrain	(B) 1.4L LUV Chassis Control Module																																																								
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2014	Sonic	Powertrain	(C) 1.6L LDE Chassis Control Module																																																								
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.6L LED Transmission Control Module																																																								
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2014	Sonic	Powertrain	(H) 1.8L LUW Chassis Control Module																																																								
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2014	Sonic	Powertrain	(G) 1.8L LWE Chassis Control Module																																																								
J	2014	Sonic	Powertrain	Fuel Injector Control Module																																																								
J	2014	Sonic	Chassis	Electronic Brake Control Module																																																								
J	2014	Sonic	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2014	Sonic	Chassis	Power Steering Control Module																																																								
J	2014	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2014	Sonic	Body	Body Control Module Hatchback																																																								
J	2014	Sonic	Body	Body Control Module Sedan																																																								
J	2014	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2014	Sonic	Body	Passenger Presence Module																																																								
J	2014	Sonic	Body	Instrument Cluster																																																								
J	2014	Sonic	Body	Radio																																																								
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2014	Sonic	Body	HVAC Control Module Heater Only (C41)																																																								
J	2014	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2014	Sonic	Body	HVAC Control Module Single Zone (C60)																																																								
J	2014	Sonic	Body	Front Seat Heating Control Module																																																								
J	2014	Sonic	Body	Parking Assist Control Module																																																								
J	2014	Sonic	Body	Frontview Camera Module																																																								
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.5L L2B Transmission Control Module																																																								
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																								
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.8L LMD Transmission Control Module																																																								
J	2014	Spin	Chassis	Electronic Brake Control Module																																																								
J	2014	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2014	Spin	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2014	Spin	Body	Body Control Module																																																								
J	2014	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2014	Spin	Body	Instrument Cluster																																																								
J	2014	Spin	Body	Radio																																																								
J	2014	Spin	Body	HVAC Control Module Heater Only (C41)																																																								
J	2014	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2014	Spin	Body	HVAC Control Module Single Zone (C60)																																																								
J	2014	Spin	Body	Parking Assist Control Module																																																								
J	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																								
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																								
J	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																								
J	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																									
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2015	Aveo	Powertrain	Chassis Control Module																																																										
J	2015	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2015	Aveo	Chassis	Power Steering Control Module																																																										
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Aveo	Body	Body Control Module Hatchback																																																										
J	2015	Aveo	Body	Body Control Module Sedan																																																										
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Aveo	Body	Instrument Cluster																																																										
J	2015	Aveo	Body	Radio																																																										
J	2015	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Aveo	Body	Front Seat Heating Control Module																																																										
J	2015	Aveo	Body	Keyless Entry Control Module																																																										
J	2015	Aveo	Body	Parking Assist Control Module																																																										
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2015	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Cobalt	Body	Body Control Module																																																										
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Cobalt	Body	Instrument Cluster																																																										
J	2015	Cobalt	Body	Radio																																																										
J	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																										
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
J	2015	Cobalt	Body	Front Seat Heating Control Module																																																									
J	2015	Cobalt	Body	Parking Assist Control Module																																																									
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																									
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																									
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																									
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																									
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																									
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																									
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																									
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																									
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																									
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																									
J	2015	Cruze	Powertrain	Fuel Injector Control Module																																																									
J	2015	Cruze	Chassis	Electronic Brake Control Module																																																									
J	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2015	Cruze	Chassis	Power Steering Control Module																																																									
J	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2015	Cruze	Body	Body Control Module Hatchback																																																									
J	2015	Cruze	Body	Body Control Module Sedan																																																									
J	2015	Cruze	Body	Body Control Module Station Wagon																																																									
J	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2015	Cruze	Body	Passenger Presence Module																																																									
J	2015	Cruze	Body	Instrument Cluster																																																									
J	2015	Cruze	Body	Trailer Interface Control Module																																																									
J	2015	Cruze	Body	Radio																																																									
J	2015	Cruze	Body	Digital Radio Receiver Control Module																																																									
J	2015	Cruze	Body	Multimedia Player Interface Module																																																									
J	2015	Cruze	Body	Mobile Telephone Control Module																																																									
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																									
J	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																									
J	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																									
J	2015	Cruze	Body	Front Seat Heating Control Module																																																									
J	2015	Cruze	Body	Keyless Entry Control Module																																																									
J	2015	Cruze	Body	Right Side Object Detection Control Module																																																									
J	2015	Cruze	Body	Left Side Object Detection Control Module																																																									
J	2015	Cruze	Body	Parking Assist Control Module																																																									
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																									
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2015	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																									
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	1.6L LED Transmission Control Module																																																										
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2015	Sonic	Powertrain	Chassis Control Module																																																										
J	2015	Sonic	Powertrain	Fuel Injector Control Module																																																										
J	2015	Sonic	Chassis	Electronic Brake Control Module																																																										
J	2015	Sonic	Chassis	Power Steering Control Module																																																										
J	2015	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Sonic	Body	Body Control Module Hatchback																																																										
J	2015	Sonic	Body	Body Control Module Sedan																																																										
J	2015	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Sonic	Body	Passenger Presence Module																																																										
J	2015	Sonic	Body	Instrument Cluster																																																										
J	2015	Sonic	Body	Radio																																																										
J	2015	Sonic	Body	Telematics Communication Interface Control Module																																																										
J	2015	Sonic	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Sonic	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Sonic	Body	Front Seat Heating Control Module																																																										
J	2015	Sonic	Body	Parking Assist Control Module																																																										
J	2015	Sonic	Body	Frontview Camera Module																																																										
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.5L L2B Transmission Control Module																																																										
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
J	2015	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2015	Spin	Chassis	Electronic Brake Control Module																																																										
J	2015	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Spin	Body	Body Control Module																																																										
J	2015	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Spin	Body	Instrument Cluster																																																										
J	2015	Spin	Body	Radio																																																										
J	2015	Spin	Body	Telematics Communication Interface Control Module																																																										
J	2015	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Spin	Body	Front Seat Heating Control Module																																																										
J	2015	Spin	Body	Parking Assist Control Module																																																										
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
J	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
J	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
J	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2016	Aveo	Powertrain	Chassis Control Module																																																										
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																									
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2016	Aveo	Chassis	Power Steering Control Module																																																										
J	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Aveo	Body	Body Control Module Hatchback																																																										
J	2016	Aveo	Body	Body Control Module Sedan																																																										
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Aveo	Body	Instrument Cluster																																																										
J	2016	Aveo	Body	Radio																																																										
J	2016	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Aveo	Body	Front Seat Heating Control Module																																																										
J	2016	Aveo	Body	Parking Assist Control Module																																																										
J	2016	Aveo	Body	Keyless Entry Control Module																																																										
J	2016	Aveo	Body	Frontview Camera Module																																																										
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2016	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Cobalt	Body	Body Control Module																																																										
J	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Cobalt	Body	Instrument Cluster																																																										
J	2016	Cobalt	Body	Radio Other																																																										
J	2016	Cobalt	Body	Radio (IOB)																																																										
J	2016	Cobalt	Body	Radio (UF7)																																																										
J	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
J	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
J	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
J	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
J	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
J	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2016	Cruze	Powertrain	Fuel Injector Control Module																																																										
J	2016	Cruze	Powertrain	Chassis Control Module																																																										
J	2016	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2016	Cruze	Chassis	Power Steering Control Module																																																										
J	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Cruze	Body	Body Control Module Hatchback																																																										
J	2016	Cruze	Body	Body Control Module Sedan																																																										
J	2016	Cruze	Body	Body Control Module Station Wagon																																																										
J	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Cruze	Body	Passenger Presence Module																																																										
J	2016	Cruze	Body	Instrument Cluster																																																										
J	2016	Cruze	Body	Trailer Interface Control Module																																																										
J	2016	Cruze	Body	Radio Other																																																									
J	2016	Cruze	Body	Radio (UF7)																																																										
J	2016	Cruze	Body	Multimedia Player Interface Module																																																										
J	2016	Cruze	Body	Mobile Telephone Control Module																																																										
J	2016	Cruze	Body	Telematics Communication Interface Control Module																																																										
J	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
J	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																										
J	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																										
J	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																										
J	2016	Cruze	Body	Front Seat Heating Control Module																																																										
J	2016	Cruze	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2016	Cruze	Body	Right Side Object Detection Control Module																																																									
J	2016	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2016	Cruze	Body	Parking Assist Control Module																																																										
J	2016	Cruze	Body	Steering Column Lock Control Module																																																										
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module																																																										
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2016	Sonic	Powertrain	Chassis Control Module																																																										
J	2016	Sonic	Powertrain	Fuel Injector Control Module																																																										
J	2016	Sonic	Chassis	Electronic Brake Control Module																																																										
J	2016	Sonic	Chassis	Power Steering Control Module																																																										
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Sonic	Body	Body Control Module Hatchback																																																										
J	2016	Sonic	Body	Body Control Module Sedan																																																										
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Sonic	Body	Passenger Presence Module																																																										
J	2016	Sonic	Body	Instrument Cluster																																																										
J	2016	Sonic	Body	Radio Other																																																									
J	2016	Sonic	Body	Radio (UF7)																																																									
J	2016	Sonic	Body	Radio (UH7)																																																									
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7																																																									
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)																																																									
J	2016	Sonic	Body	Front Seat Heating Control Module																																																										
J	2016	Sonic	Body	Parking Assist Control Module																																																										
J	2016	Sonic	Body	Frontview Camera Module																																																										
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module																																																										
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2016	Spin	Chassis	Electronic Brake Control Module																																																										
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Spin	Body	Body Control Module																																																										
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Spin	Body	Instrument Cluster																																																										
J	2016	Spin	Body	Radio																																																										
J	2016	Spin	Body	Telematics Communication Interface Control Module																																																										
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Spin	Body	Front Seat Heating Control Module																																																										
J	2016	Spin	Body	Parking Assist Control Module																																																										
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																										
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module													V	V	V																																										
K	2006	ALL	Powertrain	Transmission Control Module																																																										
K	2006	ALL	Chassis	Electronic Brake Control Module																																																										
K	2006	ALL	Body	Remote Function Actuation																																																										
K	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																				V
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																										
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module													V	V	V																																										
K	2007	ALL	Powertrain	Transmission Control Module																																																										
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module																																																										
K	2007	ALL	Chassis	Teves Electronic Brake Control Module																																																										
K	2007	ALL	Body	Remote Function Actuation																																																										
K	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																				V
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																										
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module													V	V	V																																										
K	2008	ALL	Powertrain	Transmission Control Module																																																										
K	2008	ALL	Chassis	Electronic Brake Control Module																																																										
K	2008	ALL	Body	Remote Function Actuation																																																										
K	2008	ALL	Body	Supplemental Inflatable Restraint																																					V																				V
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																										
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module													V	V	V																																										
K	2009	ALL	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2009	ALL	Chassis	Electronic Brake Control Module																																																								
K	2009	ALL	Body	Remote Function Actuation																																																								
K	2009	ALL	Body	Supplemental Inflatable Restraint																																						V																		V
K	2010	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																									
K	2010	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module													V	V	V																																									
K	2010	ALL	Powertrain	Transmission Control Module																																																								
K	2010	ALL	Chassis	Electronic Brake Control Module																																																								
K	2010	ALL	Body	Remote Function Actuation																																																								
K	2010	ALL	Body	Supplemental Inflatable Restraint																																															V									
K	2011	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																									
K	2011	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module													V	V	V																																									
K	2011	ALL	Powertrain	Transmission Control Module																																																								
K	2011	ALL	Chassis	Electronic Brake Control Module																																																								
K	2011	ALL	Body	Remote Function Actuation																																																								
K	2011	ALL	Body	Supplemental Inflatable Restraint																																															V									
K	2012	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																									
K	2012	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module													V	V	V																																									
K	2012	ALL	Powertrain	Transmission Control Module																																																								
K	2012	ALL	Chassis	Electronic Brake Control Module																																																								
K	2012	ALL	Body	Remote Function Actuation																																																								
K	2012	ALL	Body	Supplemental Inflatable Restraint																																															V									
K	2013	Onix	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																									
K	2013	Onix	Powertrain	(0)1.0L L4 LA2 Engine Control Module													V	V	V																																									
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																								
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																								
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																								
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																								
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2013	Onix	Powertrain	Transmission Control Module																																																								
K	2013	Onix	Powertrain	Transmission Control Module																																																								
K	2013	Onix	Chassis	Electronic Brake Control Module																																																								
K	2013	Onix	Chassis	Electronic Brake Control Module																																																								
K	2013	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2013	Onix	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2013	Onix	Body	Body Control Module																																																								
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																															V									
K	2013	Onix	Body	Instrument Cluster																																																								
K	2013	Onix	Body	Radio																																																								
K	2013	Onix	Body	Parking Assist Control Module																																																								
K	2013	Onix	Body	Remote Function Actuation																																																								
K	2013	Prisma	Powertrain	Engine Control Module																																																								
K	2013	Prisma	Powertrain	Transmission Control Module																																																								
K	2013	Prisma	Chassis	Electronic Brake Control Module																																																								
K	2013	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2013	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2013	Prisma	Body	Body Control Module																																																								
K	2013	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2013	Prisma	Body	Instrument Cluster																																																								
K	2013	Prisma	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2013	Prisma	Body	Parking Assist Control Module																																																								
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																									
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module																																																									
K	2014	Onix	Chassis	Electronic Brake Control Module																																																									
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																									
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2014	Onix	Body	Body Control Module																																																									
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2014	Onix	Body	Instrument Cluster																																																									
K	2014	Onix	Body	Radio																																																									
K	2014	Onix	Body	Parking Assist Control Module																																																									
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module																																																									
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																									
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																									
K	2014	Prisma	Chassis	Electronic Brake Control Module																																																									
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																									
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2014	Prisma	Body	Body Control Module																																																									
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2014	Prisma	Body	Instrument Cluster																																																									
K	2014	Prisma	Body	Radio																																																									
K	2014	Prisma	Body	Parking Assist Control Module																																																									
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																									
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module																																																									
K	2015	Onix	Chassis	Electronic Brake Control Module																																																									
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2015	Onix	Body	Body Control Module																																																									
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2015	Onix	Body	Instrument Cluster																																																									
K	2015	Onix	Body	Radio																																																									
K	2015	Onix	Body	Parking Assist Control Module																																																									
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2015	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																									
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2015	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																									
K	2015	Prisma	Chassis	Electronic Brake Control Module																																																									
K	2015	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2015	Prisma	Body	Body Control Module																																																									
K	2015	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2015	Prisma	Body	Instrument Cluster																																																									
K	2015	Prisma	Body	Radio																																																									
K	2015	Prisma	Body	Parking Assist Control Module																																																									
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2016	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																									
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2016	Onix	Powertrain	1.4L LKK Transmission Control Module																																																									
K	2016	Onix	Chassis	Electronic Brake Control Module																																																									
K	2016	Onix	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2016	Onix	Body	Body Control Module																																																									
K	2016	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2016	Onix	Body	Instrument Cluster																																																									
K	2016	Onix	Body	Radio																																																									
K	2016	Onix	Body	Parking Assist Control Module																																																									
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2016	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																									
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2016	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																									
K	2016	Prisma	Chassis	Electronic Brake Control Module																																																									
K	2016	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2016	Prisma	Body	Body Control Module																																																									
K	2016	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2016	Prisma	Body	Instrument Cluster																																																									
K	2016	Prisma	Body	Radio																																																									
K	2016	Prisma	Body	HVAC Control Module																																																									
K	2016	Prisma	Body	Front Seat Heating Control Module																																																									
K	2016	Prisma	Body	Parking Assist Control Module																																																									
L	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V		V																												
L	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
L	2004	ALL	Powertrain	Transmission Control Module																										V																															
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																									
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																									
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2004	ALL	Body	ISU																																											V													
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																										
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
L	2005	ALL	Powertrain	Transmission Control Module																										V																														
L	2005	ALL	Chassis	Anti-lock Brake System																																																								
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2005	ALL	Body	ISU																																											V													
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																										
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module													V	V	V																																									
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																										V																														
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																								
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																								
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2006	ALL	Body	ISU																																											V													
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module													V	V	V																																									
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																										
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																											V		V																											
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module													V	V	V																																									
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module													V	V	V																																									
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector																																																								
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed																										V																														
L	2007	ALL	Chassis	Electronic Brake Control Module																																																								
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2007	ALL	Body	ISU																																											V													
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																											V																													
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																											V		V																											
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																											V																													
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed																										V																														
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																V																								
L	2008	ALL	Chassis	Electronic Brake Control Module																																																								
L	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2008	ALL	Body	ISU																																											V													
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																											V																													
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																											V		V																											
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																											V																													
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
L	2009	ALL	Chassis	Electronic Brake Control Module																																																								
L	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2009	ALL	Body	ISU																																											V													
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																											V																													
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																											V																													
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																											V		V																											
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																V																								
L	2010	ALL	Chassis	Electronic Brake Control Module																																																								
L	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2010	ALL	Body	ISU																																											V													
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																											V																													
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																											V																													

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																											V		V																												
L	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
L	2011	ALL	Chassis	Electronic Brake Control Module																																																								
L	2011	ALL	Body	Supplemental Inflatable Restraint																																																							
L	2011	ALL	Body	ISU																																									V														
M	2004	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module													V	V	V																																								
M	2004	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module													V	V	V																																								
M	2004	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																								
M	2004	ALL	Chassis	Anti-lock Brake System																																																							
M	2004	ALL	Body	Remote Function Actuation																																																						
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																						
M	2005	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																								
M	2005	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module													V	V	V																																								
M	2005	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module													V	V	V																																								
M	2005	ALL	Chassis	Anti-lock Brake System																																																							
M	2005	ALL	Body	Remote Function Actuation																																																						
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																						
M	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																								
M	2006	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module													V	V	V																																								
M	2006	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module													V	V	V																																								
M	2006	ALL	Chassis	Anti-lock Brake System																																																						
M	2006	ALL	Body	Remote Function Actuation																																																						
M	2006	ALL	Body	Supplemental Inflatable Restraint																																																						
M	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																								
M	2007	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module													V	V	V																																								
M	2007	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module													V	V	V																																								
M	2007	ALL	Chassis	Anti-lock Brake System																																																						
M	2007	ALL	Body	Remote Function Actuation																																																						
M	2007	ALL	Body	Supplemental Inflatable Restraint																																																						
M	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																								
M	2008	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module													V	V	V																																								
M	2008	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module													V	V	V																																								
M	2008	ALL	Chassis	Anti-lock Brake System																																																						
M	2008	ALL	Body	Remote Function Actuation																																																						
M	2008	ALL	Body	Supplemental Inflatable Restraint																																																						
M	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module													V	V	V																																								
M	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module													V	V	V																																								
M	2009	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module													V	V	V																																								
M	2009	ALL	Chassis	Anti-lock Brake System																																																						
M	2009	ALL	Body	Remote Function Actuation																																																						
M	2009	ALL	Body	Supplemental Inflatable Restraint																																																						
M	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																						
M	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																						
M	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																						
M	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																						
M	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																						
M	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																						
M	2010	Spark	Powertrain	Transmission Control Module																																																						
M	2010	Spark	Chassis	Electronic Brake Control Module																																																						
M	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																						
M	2010	Spark	Chassis	Electric Power Steering Control Module																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
M	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2010	Spark	Body	Passenger Presence Module																																																								
M	2010	Spark	Body	Instrument Cluster																																																								
M	2011	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																													V																											
M	2011	Caprice	Powertrain	Transmission Control Module																																V	V																							
M	2011	Caprice	Powertrain	Fuel Pump Control Module																																																								
M	2011	Caprice	Chassis	Electronic Brake Control Module																																																								
M	2011	Caprice	Body	Body Control Module			V																																			V	V																	
M	2011	Caprice	Body	HVAC Control Module																																								V																
M	2011	Caprice	Body	Instrument Panel Cluster																													V											V																
M	2011	Caprice	Body	Passenger Presence System																																					V																		
M	2011	Caprice	Body	Radio																																																							
M	2011	Caprice	Body	Remote Control Door Lock Receiver																																																							
M	2011	Caprice	Body	Supplemental Inflatable Restraint																																					V																		V
M	2011	Caprice	Body	Theft Deterrent Module																																																							
M	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
M	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
M	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
M	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
M	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																								
M	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																								
M	2011	Spark	Powertrain	Transmission Control Module																																																								
M	2011	Spark	Chassis	Electronic Brake Control Module																																																								
M	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
M	2011	Spark	Chassis	Electric Power Steering Control Module																																																								
M	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2011	Spark	Body	Passenger Presence Module																																																								
M	2011	Spark	Body	Instrument Cluster																																																								
M	2012	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																												V	V	V																											
M	2012	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																														V																											
M	2012	Caprice	Powertrain	Transmission Control Module																																V	V																							
M	2012	Caprice	Powertrain	Fuel Pump Control Module																																																								
M	2012	Caprice	Chassis	Electronic Brake Control Module																																																								
M	2012	Caprice	Body	Body Control Module			V																																			V	V																	
M	2012	Caprice	Body	HVAC Control Module																																								V																
M	2012	Caprice	Body	Instrument Panel Cluster																													V											V																
M	2012	Caprice	Body	Passenger Presence System																																					V																		
M	2012	Caprice	Body	Radio																																																							
M	2012	Caprice	Body	Remote Control Door Lock Receiver																																																								
M	2012	Caprice	Body	Supplemental Inflatable Restraint																																																								
M	2012	Caprice	Body	Theft Deterrent Module																																																								
M	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
M	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
M	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
M	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
M	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																								
M	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
M	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																								
M	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																									
M	2012	Spark	Powertrain	Transmission Control Module																																																									
M	2012	Spark	Chassis	Electronic Brake Control Module																																																									
M	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
M	2012	Spark	Chassis	Electric Power Steering Control Module																																																									
M	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2012	Spark	Body	Passenger Presence Module																																																									
M	2012	Spark	Body	Instrument Cluster																																																									
M	2013	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																												V	V	V																											
M	2013	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																														V																											
M	2013	Caprice	Powertrain	Transmission Control Module																																	V	V																							
M	2013	Caprice	Powertrain	Fuel Pump Control Module																																																									
M	2013	Caprice	Chassis	Electronic Brake Control Module																																																									
M	2013	Caprice	Body	Body Control Module			V																																				V	V																
M	2013	Caprice	Body	HVAC Control Module																																									V															
M	2013	Caprice	Body	Instrument Panel Cluster																														V											V															
M	2013	Caprice	Body	Passenger Presence System																																						V																		
M	2013	Caprice	Body	Radio																																																								
M	2013	Caprice	Body	Remote Control Door Lock Receiver																																																									
M	2013	Caprice	Body	Supplemental Inflatable Restraint																																																									
M	2013	Caprice	Body	Theft Deterrent Module																																																									
M	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
M	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																									
M	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																									
M	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																									
M	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																									
M	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																									
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																									
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																									
M	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																									
M	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																									
M	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																									
M	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																									
M	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																									
M	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
M	2013	Spark	Powertrain	Fuel Injector Control Module																																																									
M	2013	Spark	Chassis	Electronic Brake Control Module																																																									
M	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
M	2013	Spark	Chassis	Power Steering Control Module																																																									
M	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
M	2013	Spark	Body	Body Control Module																																																									
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2013	Spark	Body	Passenger Presence Module																																																									
M	2013	Spark	Body	Instrument Cluster																																																									
M	2013	Spark	Body	Radio																																																									
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																									
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
M	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																									
M	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2014	Spark	Chassis	Power Steering Control Module																																																										
M	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2014	Spark	Body	Body Control Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Passenger Presence Module																																																										
M	2014	Spark	Body	Instrument Cluster																																																										
M	2014	Spark	Body	Radio																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark	Body	Keyless Entry Control Module																																																										
M	2014	Spark EV	Powertrain	Engine Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
M	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
M	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2014	Spark EV	Chassis	Power Steering Control Module																																																										
M	2014	Spark EV	Body	Body Control Module																																																										
M	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark EV	Body	Passenger Presence Module																																																										
M	2014	Spark EV	Body	Instrument Cluster																																																										
M	2014	Spark EV	Body	Radio																																																										
M	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
M	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																									
M	2014	Spark EV	Body	Coolant Heater Control Module																																																										
M	2014	Spark EV	Body	Keyless Entry Control Module																																																										
M	2014	Spark EV	Body	Battery Charger Control Module																																																										
M	2014	Spark EV	Body	DC Charging Control Module																																																										
M	2014	Spark EV	Body	Battery Energy Control Module																																																										
M	2015	Matiz	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2015	Matiz	Chassis	Electronic Brake Control Module																																																										
M	2015	Matiz	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Matiz	Body	Keyless Entry Control Module																																																										
M	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
M	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
M	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2015	Spark	Chassis	Electronic Brake Control Module																																																										
M	2015	Spark	Chassis	Electronic Brake Control Module																																																										
M	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2015	Spark	Chassis	Power Steering Control Module																																																										
M	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2015	Spark	Body	Body Control Module																																																										
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Spark	Body	Passenger Presence Module																																																										
M	2015	Spark	Body	Instrument Cluster																																																										
M	2015	Spark	Body	Instrument Cluster																																																										
M	2015	Spark	Body	Tire Pressure Indicator Module																																																										
M	2015	Spark	Body	Radio																																																										
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2015	Spark	Body	Keyless Entry Control Module																																																										
M	2015	Spark EV	Powertrain	Engine Control Module																																																										
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
M	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
M	2015	Spark EV	Chassis	Electronic Brake Control Module																																																									
M	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2015	Spark EV	Chassis	Power Steering Control Module																																																										
M	2015	Spark EV	Body	Body Control Module																																																										
M	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Spark EV	Body	Passenger Presence Module																																																										
M	2015	Spark EV	Body	Instrument Cluster																																																										
M	2015	Spark EV	Body	Radio																																																										
M	2015	Spark EV	Body	HVAC Control Module																																																										
M	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2015	Spark EV	Body	Coolant Heater Control Module																																																										
M	2015	Spark EV	Body	Keyless Entry Control Module																																																										
M	2015	Spark EV	Body	Battery Charger Control Module																																																										
M	2015	Spark EV	Body	DC Charging Control Module																																																										
M	2015	Spark EV	Body	Battery Energy Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2016	Spark	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2016	Spark	Chassis	Power Steering Control Module																																																										
M	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2016	Spark	Body	Body Control Module																																																										
M	2016	Spark	Body	Body Control Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Instrument Cluster																																																										
M	2016	Spark	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
M	2016	Spark	Body	Radio																																																								
M	2016	Spark	Body	Telematics Communication Interface Control Module																																																								
M	2016	Spark	Body	Keyless Entry Control Module																																																								
M	2016	Spark EV	Powertrain	Engine Control Module																																																								
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																								
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																								
M	2016	Spark EV	Powertrain	Drive Motor Control Module																																																								
M	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								
M	2016	Spark EV	Chassis	Electronic Brake Control Module																																																								
M	2016	Spark EV	Chassis	Parking Brake Control Module																																																								
M	2016	Spark EV	Chassis	Power Steering Control Module																																																								
M	2016	Spark EV	Body	Body Control Module																																																								
M	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
M	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2016	Spark EV	Body	Passenger Presence Module																																																								
M	2016	Spark EV	Body	Instrument Cluster																																																								
M	2016	Spark EV	Body	Radio																																																								
M	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																								
M	2016	Spark EV	Body	HVAC Control Module																																																								
M	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																								
M	2016	Spark EV	Body	Coolant Heater Control Module																																																								
M	2016	Spark EV	Body	Keyless Entry Control Module																																																								
M	2016	Spark EV	Body	Frontview Camera Module																																																								
M	2016	Spark EV	Body	Battery Charger Control Module																																																								
M	2016	Spark EV	Body	DC Charging Control Module																																																								
M	2016	Spark EV	Body	Battery Energy Control Module																																																								
N	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																									
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																									
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																											V			V																										
N	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																											V			V																										
N	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																											V			V																										
N	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																										
N	2004	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																										V																														
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																								
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																								
N	2004	Optra	Body	Remote Function Actuation																																																								
N	2004	Optra	Body	Supplemental Inflatable Restraint																																																								
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module													V	V	V																																									
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																V	V	V		V	V	V	V		V																															
N	2004	Classic	Chassis	Anti-lock Brake System																																																								
N	2004	Classic	Body	Body Control Module																																																								
N	2004	Classic	Body	Radio																																																								
N	2004	Classic	Body	Remote Function Actuation																																															V									
N	2004	Classic	Body	Supplemental Inflatable Restraint																																					V																			
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Engine Control Module													V	V																																										
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Transmission Control Module																V	V	V		V	V	V	V		V																															
N	2004	Alero (Export)	Chassis	Anti-lock Brake System																																																								
N	2004	Alero (Export)	Body	Body Control Module																																																								
N	2004	Alero (Export)	Body	Instrument Panel Cluster																																						V																		
N	2004	Alero (Export)	Body	Radio																																															V								V	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
N	2004	Alero (Export)	Body	Supplemental Inflatable Restraint																																					V																			
N	2004	Alero (Export)	Body	Vehicle Theft Deterrent																																					V	V										V							
N	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																								
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V																																										
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																										V			V																											
N	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																										V			V																											
N	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																										V			V																											
N	2005	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																										V			V																											
N	2005	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																							
N	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																									V																															
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																							
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																							
N	2005	Optra	Body	Remote Function Actuation																																																							
N	2005	Optra	Body	Supplemental Inflatable Restraint																																																							
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module													V	V	V																																								
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																V	V	V		V	V	V	V		V																															
N	2005	Classic	Chassis	Anti-lock Brake System																																																							
N	2005	Classic	Body	Body Control Module																																																						
N	2005	Classic	Body	Radio																																																						
N	2005	Classic	Body	Remote Function Actuation																																																V							
N	2005	Classic	Body	Supplemental Inflatable Restraint																																					V																		V
N	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																								
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																								
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																										V			V																											
N	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																										V			V																											
N	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																										V			V																											
N	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																										V			V																											
N	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																										V			V																											
N	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																							
N	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																									V																															
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																						
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																							
N	2006	ALL	Body	Remote Function Actuation																																																						
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																V							
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																V							
N	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																								
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																								
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																										V			V																											
N	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																										V			V																											
N	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																										V			V																											
N	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																										V		V																											
N	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																										V			V																											
N	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																						
N	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																									V																															
N	2007	ALL	Powertrain	Transmission Control Module 5 Speed																									V																															
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																						
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																						
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																						
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																						
N	2007	ALL	Chassis	Tire Pressure Monitor																																																						
N	2007	ALL	Body	Remote Function Actuation																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
N	2007	ALL	Body	Supplemental Inflatable Restraint																																																V							
N	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																								
N	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																								
N	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module													V	V	V																																								
N	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																										
N	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																											V			V																										
N	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																											V		V																										
N	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																											V		V																										
N	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																										
N	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																								
N	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																										V																														
N	2008	ALL	Powertrain	Transmission Control Module 5 Speed																										V																														
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																							
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																							
N	2008	ALL	Chassis	Tire Pressure Monitor																																																							
N	2008	ALL	Body	Remote Function Actuation																																																							
N	2008	ALL	Body	Supplemental Inflatable Restraint																																																V							
N	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																								
N	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																								
N	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module													V	V	V																																								
N	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																										
N	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																											V			V																										
N	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																											V		V																										
N	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																										
N	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																							
N	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																							
N	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																										V																														
N	2009	ALL	Powertrain	Transmission Control Module 5 Speed																										V																														
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																							
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																							
N	2009	ALL	Chassis	Tire Pressure Monitor																																																							
N	2009	ALL	Body	Remote Function Actuation																																																							
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2010	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																								
N	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module													V	V	V																																								
N	2010	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																										
N	2010	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																											V		V																										
N	2010	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																										
N	2010	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																							
N	2010	ALL	Powertrain	MFA Transmission Control Module 4 Speed																										V																														
N	2010	ALL	Powertrain	Transmission Control Module 5 Speed																										V																														
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																							
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																							
N	2010	ALL	Chassis	Tire Pressure Monitor																																																							
N	2010	ALL	Body	Remote Function Actuation																																																							
N	2010	ALL	Body	Remote Function Actuation																																																V							
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
N	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module													V	V	V																																									
N	2011	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																										
N	2011	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																											V		V																											
N	2011	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																										
N	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																							
N	2011	ALL	Powertrain	MFA Transmission Control Module 4 Speed																										V																														
N	2011	ALL	Powertrain	Transmission Control Module 5 Speed																										V																														
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																							
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																							
N	2011	ALL	Chassis	Tire Pressure Monitor																																																							
N	2011	ALL	Body	Remote Function Actuation																																																							
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2012	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																									
N	2012	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module													V	V	V																																									
N	2012	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																										
N	2012	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																											V		V																											
N	2012	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																							
N	2012	ALL	Powertrain	MFA Transmission Control Module 4 Speed																										V																														
N	2012	ALL	Powertrain	Transmission Control Module 5 Speed																										V																														
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																							
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																							
N	2012	ALL	Chassis	Tire Pressure Monitor																																																							
N	2012	ALL	Body	Remote Function Actuation																																																							
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2013	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module													V	V	V																																									
N	2013	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module													V	V	V																																									
N	2013	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V			V																										
N	2013	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																											V		V																											
N	2013	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																							
N	2013	ALL	Powertrain	MFA Transmission Control Module 4 Speed																										V																														
N	2013	ALL	Powertrain	Transmission Control Module 5 Speed																										V																														
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																							
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																							
N	2013	ALL	Chassis	Tire Pressure Monitor																																																							
N	2013	ALL	Body	Remote Function Actuation																																																							
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																							
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																							
N	2014	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																							
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																							
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																							
N	2014	Caprice	Powertrain	(2) 6.0L L77 Chassis Control Module																																																							
N	2014	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																							
N	2014	Caprice	Chassis	Electronic Brake Control Module																																																							
N	2014	Caprice	Chassis	Parking Brake Control Module																																																							
N	2014	Caprice	Chassis	Power Steering Control Module																																																							
N	2014	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																							
N	2014	Caprice	Body	Body Control Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
N	2014	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2014	Caprice	Body	Passenger Presence Module																																																										
N	2014	Caprice	Body	Instrument Cluster																																																										
N	2014	Caprice	Body	Radio Controls																																																										
N	2014	Caprice	Body	HVAC Controls																																																										
N	2014	Caprice	Body	Headlamp Control Module																																																										
N	2014	Caprice	Body	Trailer Interface Control Module																																																										
N	2014	Caprice	Body	Radio																																																										
N	2014	Caprice	Body	HVAC Control Module																																																										
N	2014	Caprice	Body	Parking Assist Control Module																																																										
N	2014	Caprice	Body	Frontview Camera Module																																																										
N	2014	Caprice	Body	Steering Column Lock Control Module																																																										
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
N	2015	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
N	2015	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
N	2015	Caprice	Powertrain	Fuel Injector Control Module																																																										
N	2015	Caprice	Chassis	Electronic Brake Control Module																																																										
N	2015	Caprice	Chassis	Parking Brake Control Module																																																										
N	2015	Caprice	Chassis	Power Steering Control Module																																																										
N	2015	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2015	Caprice	Chassis	Suspension Control Module																																																										
N	2015	Caprice	Body	Body Control Module																																																										
N	2015	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2015	Caprice	Body	Passenger Presence Module																																																										
N	2015	Caprice	Body	Instrument Cluster																																																										
N	2015	Caprice	Body	Head-Up Display Module																																																										
N	2015	Caprice	Body	Radio Controls																																																										
N	2015	Caprice	Body	HVAC Controls																																																										
N	2015	Caprice	Body	Headlamp Control Module																																																										
N	2015	Caprice	Body	Trailer Interface Control Module																																																										
N	2015	Caprice	Body	Radio																																																										
N	2015	Caprice	Body	Telematics Communication Interface Control Module																																																										
N	2015	Caprice	Body	HVAC Control Module																																																										
N	2015	Caprice	Body	Right Side Object Detection Control Module																																																										
N	2015	Caprice	Body	Left Side Object Detection Control Module																																																										
N	2015	Caprice	Body	Parking Assist Control Module																																																										
N	2015	Caprice	Body	Frontview Camera Module																																																										
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
N	2016	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
N	2016	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
N	2016	Caprice	Powertrain	Fuel Injector Control Module																																																										
N	2016	Caprice	Chassis	Electronic Brake Control Module																																																										
N	2016	Caprice	Chassis	Parking Brake Control Module																																																										
N	2016	Caprice	Chassis	Power Steering Control Module																																																										
N	2016	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
N	2016	Caprice	Chassis	Suspension Control Module																																																									
N	2016	Caprice	Body	Body Control Module																																																									
N	2016	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2016	Caprice	Body	Passenger Presence Module																																																										
N	2016	Caprice	Body	Instrument Cluster																																																										
N	2016	Caprice	Body	Head-Up Display Module																																																										
N	2016	Caprice	Body	Radio Controls																																																										
N	2016	Caprice	Body	HVAC Controls																																																										
N	2016	Caprice	Body	Trailer Interface Control Module																																																										
N	2016	Caprice	Body	Radio																																																										
N	2016	Caprice	Body	Telematics Communication Interface Control Module																																																										
N	2016	Caprice	Body	HVAC Control Module																																																										
N	2016	Caprice	Body	Seat Memory Control Module - Driver																																																										
N	2016	Caprice	Body	Right Side Object Detection Control Module																																																										
N	2016	Caprice	Body	Left Side Object Detection Control Module																																																										
N	2016	Caprice	Body	Parking Assist Control Module																																																										
N	2016	Caprice	Body	Frontview Camera Module																																																										
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																										
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																										
P	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																										
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																										
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																										
P	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																										
P	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																										
P	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																										
P	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																										
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																										
P	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																										
P	2010	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2010	Cruze	Body	Body Control Module																																																										
P	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2010	Cruze	Body	Passenger Presence Module																																																										
P	2010	Cruze	Body	Instrument Cluster																																																										
P	2010	Cruze	Body	Trailer Interface Control Module																																																										
P	2010	Cruze	Body	Radio																																																										
P	2010	Cruze	Body	Multimedia Player Interface Module																																																										
P	2010	Cruze	Body	Mobile Telephone Control Module																																																										
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
P	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
P	2010	Cruze	Body	Keyless Entry Control Module																																																										
P	2010	Cruze	Body	Parking Assist Control Module																																																										
P	2010	Cruze	Body	Steering Column Lock Control Module																																																										
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																										
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																									
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																									
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																									
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																									
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																									
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																									
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																									
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																									
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																									
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																									
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2011	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2011	Cruze	Body	Body Control Module																																																									
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2011	Cruze	Body	Passenger Presence Module																																																									
P	2011	Cruze	Body	Instrument Cluster																																																									
P	2011	Cruze	Body	Trailer Interface Control Module																																																									
P	2011	Cruze	Body	Radio																																																									
P	2011	Cruze	Body	Multimedia Player Interface Module																																																									
P	2011	Cruze	Body	Mobile Telephone Control Module																																																									
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
P	2011	Cruze	Body	Keyless Entry Control Module																																																									
P	2011	Cruze	Body	Parking Assist Control Module																																																									
P	2011	Cruze	Body	Steering Column Lock Control Module																																																									
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																									
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
P	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																									
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																									
P	2012	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2012	Cruze	Body	Body Control Module Hatchback																																																									
P	2012	Cruze	Body	Body Control Module Sedan																																																									
P	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2012	Cruze	Body	Passenger Presence Module																																																									
P	2012	Cruze	Body	Instrument Cluster																																																									
P	2012	Cruze	Body	Trailer Interface Control Module																																																									
P	2012	Cruze	Body	Radio																																																									
P	2012	Cruze	Body	Multimedia Player Interface Module																																																									
P	2012	Cruze	Body	Mobile Telephone Control Module																																																									
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
P	2012	Cruze	Body	Keyless Entry Control Module																																																									
P	2012	Cruze	Body	Parking Assist Control Module																																																									
P	2012	Cruze	Body	Steering Column Lock Control Module																																																									
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
P	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2013	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2013	Cruze	Body	Body Control Module Hatchback																																																										
P	2013	Cruze	Body	Body Control Module Sedan																																																										
P	2013	Cruze	Body	Body Control Module Station Wagon																																																										
P	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2013	Cruze	Body	Passenger Presence Module																																																										
P	2013	Cruze	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
P	2013	Cruze	Body	Trailer Interface Control Module																																																									
P	2013	Cruze	Body	Radio																																																									
P	2013	Cruze	Body	Digital Radio Receiver Control Module																																																									
P	2013	Cruze	Body	Multimedia Player Interface Module																																																									
P	2013	Cruze	Body	Mobile Telephone Control Module																																																									
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																									
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																									
P	2013	Cruze	Body	Front Seat Heating Control Module																																																									
P	2013	Cruze	Body	Keyless Entry Control Module																																																									
P	2013	Cruze	Body	Right Side Object Detection Control Module																																																									
P	2013	Cruze	Body	Left Side Object Detection Control Module																																																									
P	2013	Cruze	Body	Parking Assist Control Module																																																									
P	2013	Cruze	Body	Steering Column Lock Control Module																																																									
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																									
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																									
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																									
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																									
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																									
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																									
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																									
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																									
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																									
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																										
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																										
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																										
P	2014	Cruze	Powertrain	Fuel Injector Control Module																																																										
P	2014	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2014	Cruze	Chassis	Power Steering Control Module																																																										
P	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2014	Cruze	Body	Body Control Module Hatchback																																																										
P	2014	Cruze	Body	Body Control Module Sedan																																																										
P	2014	Cruze	Body	Body Control Module Station Wagon																																																										
P	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2014	Cruze	Body	Passenger Presence Module																																																										
P	2014	Cruze	Body	Instrument Cluster																																																										
P	2014	Cruze	Body	Trailer Interface Control Module																																																										
P	2014	Cruze	Body	Radio																																																										
P	2014	Cruze	Body	Digital Radio Receiver Control Module																																																										
P	2014	Cruze	Body	Multimedia Player Interface Module																																																										
P	2014	Cruze	Body	Mobile Telephone Control Module																																																										
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
P	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
P	2014	Cruze	Body	Front Seat Heating Control Module																																																										
P	2014	Cruze	Body	Keyless Entry Control Module																																																										
P	2014	Cruze	Body	Right Side Object Detection Control Module																																																										
P	2014	Cruze	Body	Left Side Object Detection Control Module																																																										
P	2014	Cruze	Body	Parking Assist Control Module																																																										
P	2014	Cruze	Body	Steering Column Lock Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																											
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																											
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																											
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																											
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																											
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																									
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																									
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																									
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																									
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																									
P	2015	Cruze	Powertrain	Fuel Injector Control Module																																																									
P	2015	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2015	Cruze	Chassis	Power Steering Control Module																																																									
P	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2015	Cruze	Body	Body Control Module Hatchback																																																									
P	2015	Cruze	Body	Body Control Module Sedan																																																									
P	2015	Cruze	Body	Body Control Module Station Wagon																																																									
P	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2015	Cruze	Body	Passenger Presence Module																																																									
P	2015	Cruze	Body	Instrument Cluster																																																									
P	2015	Cruze	Body	Trailer Interface Control Module																																																									
P	2015	Cruze	Body	Radio																																																									
P	2015	Cruze	Body	Digital Radio Receiver Control Module																																																									
P	2015	Cruze	Body	Multimedia Player Interface Module																																																									
P	2015	Cruze	Body	Mobile Telephone Control Module																																																									
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																									
P	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																									
P	2015	Cruze	Body	Front Seat Heating Control Module																																																									
P	2015	Cruze	Body	Keyless Entry Control Module																																																									
P	2015	Cruze	Body	Right Side Object Detection Control Module																																																									
P	2015	Cruze	Body	Left Side Object Detection Control Module																																																									
P	2015	Cruze	Body	Parking Assist Control Module																																																									
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																									
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																									
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																									
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																									
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																									
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2016	Cruze	Powertrain	Fuel Injector Control Module																																																									
P	2016	Cruze	Powertrain	Chassis Control Module																																																									
P	2016	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2016	Cruze	Chassis	Power Steering Control Module																																																									
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2016	Cruze	Body	Body Control Module Hatchback																																																									
P	2016	Cruze	Body	Body Control Module Sedan																																																									
P	2016	Cruze	Body	Body Control Module Station Wagon																																																									
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2016	Cruze	Body	Passenger Presence Module																																																									
P	2016	Cruze	Body	Instrument Cluster																																																									
P	2016	Cruze	Body	Trailer Interface Control Module																																																									
P	2016	Cruze	Body	Radio Other																																																									
P	2016	Cruze	Body	Radio (UF7)																																																									
P	2016	Cruze	Body	Multimedia Player Interface Module																																																									
P	2016	Cruze	Body	Mobile Telephone Control Module																																																									
P	2016	Cruze	Body	Telematics Communication Interface Control Module																																																									
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																									
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																									
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																									
P	2016	Cruze	Body	Front Seat Heating Control Module																																																									
P	2016	Cruze	Body	Keyless Entry Control Module																																																									
P	2016	Cruze	Body	Right Side Object Detection Control Module																																																									
P	2016	Cruze	Body	Left Side Object Detection Control Module																																																									
P	2016	Cruze	Body	Parking Assist Control Module																																																									
P	2016	Cruze	Body	Steering Column Lock Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2011	Volt	Powertrain	Engine Control Module																																																								
R	2011	Volt	Powertrain	Trasmission Control Module																																																								
R	2011	Volt	Powertrain	Fuel Pump Control Module																																																								
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module																																																								
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																								
R	2011	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2011	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2011	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																								
R	2011	Volt	Chassis	Electronic Brake Control Module																																																								
R	2011	Volt	Chassis	Parking Brake Control Module																																																								
R	2011	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																								
R	2011	Volt	Chassis	Power Steering Control Module																																																								
R	2011	Volt	Chassis	Steering Wheel Angle Sensor Module																																																								
R	2011	Volt	Body	Body Control Module																																																								
R	2011	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2011	Volt	Body	Passenger Presence Module																																																								
R	2011	Volt	Body	Instrument Cluster																																																								
R	2011	Volt	Body	Radio																																																								
R	2011	Volt	Body	Digital Radio Receiver Control Module																																																								
R	2011	Volt	Body	Mobile Telephone Control Module																																																								
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2011	Volt	Body	Remote Heater and Air Conditioning Control Module																																																								
R	2011	Volt	Body	Electric A/C Compressor Control Module																																																								
R	2011	Volt	Body	Coolant Heater Control Module																																																								
R	2011	Volt	Body	Keyless Entry Control Module																																																								
R	2011	Volt	Body	Parking Assist Control Module																																																								
R	2011	Volt	Body	Steering Column Lock Control Module																																																								
R	2011	Volt	Body	Battery Charger Control Module																																																								
R	2011	Volt	Body	Battery Energy Control Module																																																								
R	2012	Volt	Powertrain	Engine Control Module																																																								
R	2012	Volt	Powertrain	Trasmission Control Module																																																								
R	2012	Volt	Powertrain	Fuel Pump Control Module																																																								
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module																																																								
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																								
R	2012	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2012	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2012	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																								
R	2012	Volt	Chassis	Electronic Brake Control Module																																																								
R	2012	Volt	Chassis	Parking Brake Control Module																																																								
R	2012	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																								
R	2012	Volt	Chassis	Power Steering Control Module																																																								
R	2012	Volt	Chassis	Steering Wheel Angle Sensor Module																																																								
R	2012	Volt	Body	Body Control Module																																																								
R	2012	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2012	Volt	Body	Passenger Presence Module																																																								
R	2012	Volt	Body	Instrument Cluster																																																								
R	2012	Volt	Body	Radio																																																								
R	2012	Volt	Body	Digital Radio Receiver Control Module																																																								
R	2012	Volt	Body	Mobile Telephone Control Module																																																								
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 9																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 10																																																									
R	2012	Volt	Body	Remote Heater and Air Conditioning Control Module																																																										
R	2012	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2012	Volt	Body	Coolant Heater Control Module																																																										
R	2012	Volt	Body	Keyless Entry Control Module																																																										
R	2012	Volt	Body	Parking Assist Control Module																																																										
R	2012	Volt	Body	Steering Column Lock Control Module																																																										
R	2012	Volt	Body	Battery Charger Control Module																																																										
R	2012	Volt	Body	Battery Energy Control Module																																																										
R	2013	Volt	Powertrain	Engine Control Module																																																										
R	2013	Volt	Powertrain	Trasmission Control Module																																																										
R	2013	Volt	Powertrain	Fuel Pump Control Module																																																										
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2013	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2013	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2013	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2013	Volt	Chassis	Electronic Brake Control Module																																																										
R	2013	Volt	Chassis	Parking Brake Control Module																																																										
R	2013	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2013	Volt	Chassis	Power Steering Control Module																																																										
R	2013	Volt	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2013	Volt	Body	Body Control Module																																																										
R	2013	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2013	Volt	Body	Passenger Presence Module																																																										
R	2013	Volt	Body	Instrument Cluster																																																										
R	2013	Volt	Body	Radio																																																										
R	2013	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2013	Volt	Body	Multimedia Player Interface Module																																																										
R	2013	Volt	Body	Mobile Telephone Control Module																																																										
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2013	Volt	Body	HVAC Control Module																																																										
R	2013	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2013	Volt	Body	Coolant Heater Control Module																																																										
R	2013	Volt	Body	Front Seat Heating Control Module																																																										
R	2013	Volt	Body	Keyless Entry Control Module																																																										
R	2013	Volt	Body	Parking Assist Control Module																																																										
R	2013	Volt	Body	Frontview Camera Module																																																										
R	2013	Volt	Body	Steering Column Lock Control Module																																																										
R	2013	Volt	Body	Battery Charger Control Module																																																										
R	2013	Volt	Body	Battery Energy Control Module																																																										
R	2014	Volt	Powertrain	Engine Control Module																																																										
R	2014	Volt	Powertrain	Trasmission Control Module																																																										
R	2014	Volt	Powertrain	Chassis Control Module																																																										
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2014	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2014	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2014	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2014	Volt	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2014	Volt	Chassis	Parking Brake Control Module																																																								
R	2014	Volt	Chassis	Power Steering Control Module																																																								
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module																																																								
R	2014	Volt	Body	Body Control Module																																																								
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2014	Volt	Body	Passenger Presence Module																																																								
R	2014	Volt	Body	Instrument Cluster																																																								
R	2014	Volt	Body	Radio																																																								
R	2014	Volt	Body	Digital Radio Receiver Control Module																																																								
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2014	Volt	Body	HVAC Control Module																																																								
R	2014	Volt	Body	Electric A/C Compressor Control Module																																																								
R	2014	Volt	Body	Coolant Heater Control Module																																																								
R	2014	Volt	Body	Front Seat Heating Control Module																																																								
R	2014	Volt	Body	Keyless Entry Control Module																																																								
R	2014	Volt	Body	Parking Assist Control Module																																																								
R	2014	Volt	Body	Frontview Camera Module																																																								
R	2014	Volt	Body	Steering Column Lock Control Module																																																								
R	2014	Volt	Body	Battery Charger Control Module																																																								
R	2014	Volt	Body	Battery Energy Control Module																																																								
R	2015	Volt	Powertrain	Engine Control Module																																																								
R	2015	Volt	Powertrain	Trasmission Control Module																																																								
R	2015	Volt	Powertrain	Chassis Control Module																																																								
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module																																																								
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																								
R	2015	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2015	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																								
R	2015	Volt	Chassis	Electronic Brake Control Module																																																								
R	2015	Volt	Chassis	Parking Brake Control Module																																																								
R	2015	Volt	Chassis	Power Steering Control Module																																																								
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module																																																								
R	2015	Volt	Body	Body Control Module																																																								
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2015	Volt	Body	Passenger Presence Module																																																								
R	2015	Volt	Body	Instrument Cluster																																																								
R	2015	Volt	Body	Radio																																																								
R	2015	Volt	Body	Digital Radio Receiver Control Module																																																								
R	2015	Volt	Body	Telematics Communication Interface Control Module																																																								
R	2015	Volt	Body	HVAC Control Module																																																								
R	2015	Volt	Body	Electric A/C Compressor Control Module																																																								
R	2015	Volt	Body	Coolant Heater Control Module																																																								
R	2015	Volt	Body	Front Seat Heating Control Module																																																								
R	2015	Volt	Body	Keyless Entry Control Module																																																								
R	2015	Volt	Body	Parking Assist Control Module																																																								
R	2015	Volt	Body	Frontview Camera Module																																																								
R	2015	Volt	Body	Steering Column Lock Control Module																																																								
R	2015	Volt	Body	Battery Charger Control Module																																																								
R	2015	Volt	Body	Battery Energy Control Module																																																								
R	2016	Volt	Powertrain	Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module																																																									
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2016	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2016	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2016	Volt	Chassis	Electronic Brake Control Module																																																										
R	2016	Volt	Chassis	Brake Booster Control Module																																																										
R	2016	Volt	Chassis	Power Steering Control Module																																																										
R	2016	Volt	Body	Body Control Module																																																										
R	2016	Volt	Body	Pedestrian Alert Sound Control Module																																																										
R	2016	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Volt	Body	Passenger Presence Module																																																										
R	2016	Volt	Body	Instrument Cluster																																																										
R	2016	Volt	Body	Radio Controls																																																										
R	2016	Volt	Body	HVAC Controls																																																										
R	2016	Volt	Body	Radio																																																										
R	2016	Volt	Body	Amplifier																																																										
R	2016	Volt	Body	Human Machine Interface Control Module																																																										
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 9.7																																																										
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2016	Volt	Body	HVAC Control Module																																																										
R	2016	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2016	Volt	Body	Keyless Entry Control Module																																																										
R	2016	Volt	Body	Right Side Object Detection Control Module																																																										
R	2016	Volt	Body	Left Side Object Detection Control Module																																																										
R	2016	Volt	Body	Parking Assist Control Module																																																										
R	2016	Volt	Body	Frontview Camera Module																																																										
R	2016	Volt	Body	Steering Column Lock Control Module																																																										
R	2016	Volt	Body	Battery Energy Control Module																																																										
R	2016	Volt	Body	Long Range Radar Sensor Module		V																																																								
S	2004	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2004	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module													V	V	V																																										
S	2004	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																												
S	2004	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																											V			V																												
S	2004	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																												
S	2004	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																											V			V																												
S	2004	Aveo	Powertrain	Transmission Control Module																																																										
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2004	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2004	Aveo	Body	Remote Function Actuation																																																										
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2005	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module													V	V	V																																										
S	2005	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																												
S	2005	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																											V			V																												
S	2005	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																												
S	2005	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																											V			V																												
S	2005	Aveo	Powertrain	Transmission Control Module																																																										
S	2005	Aveo	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2005	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2005	Aveo	Body	Remote Function Actuation																																																								
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2006	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module													V	V	V																																									
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																										
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																											V			V																										
S	2006	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																											V			V																										
S	2006	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																										
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																											V			V																										
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																											V			V																										
S	2006	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2006	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2006	Aveo	Body	Supplemental Inflatable Restraint																																																V								
S	2006	Aveo	Body	Remote Function Actuation																																																								
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2007	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module													V	V	V																																									
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																										
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																											V			V																										
S	2007	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																											V			V																										
S	2007	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																										
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																											V			V																										
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																											V			V																										
S	2007	Aveo	Powertrain	Transmission Control Module 4 Speed																																																								
S	2007	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2007	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2007	Aveo	Body	Supplemental Inflatable Restraint																																																V								
S	2007	Aveo	Body	Remote Function Actuation																																																								
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2008	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module													V	V	V																																									
S	2008	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module													V	V	V																																									
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																										
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																											V			V																										
S	2008	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																											V			V																										
S	2008	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																										
S	2008	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																											V			V																										
S	2008	Aveo	Powertrain	Transmission Control Module																																																								
S	2008	Aveo	Powertrain	Transmission Control Module																																																								
S	2008	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2008	Aveo	Chassis	Tire Pressure Monitor																																																								
S	2008	Aveo	Body	Supplemental Inflatable Restraint																																																V								
S	2008	Aveo	Body	Remote Function Actuation																																																								
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2009	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module													V	V	V																																									
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																										
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																											V			V																										
S	2009	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																											V			V																										
S	2009	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2009	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																											V	V	V	V																										
S	2009	Aveo	Powertrain	Transmission Control Module																																																								
S	2009	Aveo	Powertrain	Transmission Control Module																																																								
S	2009	Aveo	Powertrain	Other Auto Transmission System																																																								
S	2009	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2009	Aveo	Chassis	Tire Pressure Monitor																																																								
S	2009	Aveo	Body	Supplemental Inflatable Restraint																																																V								
S	2009	Aveo	Body	Remote Function Actuation																																																								
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2010	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module													V	V	V																																									
S	2010	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																											
S	2010	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																											V			V																											
S	2010	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																											
S	2010	Aveo	Powertrain	(6)1.6L L4 LXT Engine Control Module																											V			V																											
S	2010	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																											V	V	V	V																											
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2010	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2010	Aveo	Chassis	Tire Pressure Monitor																																																								
S	2010	Aveo	Body	Supplemental Inflatable Restraint																																																V								
S	2010	Aveo	Body	Remote Function Actuation																																																								
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
S	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																								
S	2010	Sail	Powertrain	Transmission Control Module																																																								
S	2010	Sail	Chassis	Electronic Brake Control Module																																																								
S	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2011	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module													V	V	V																																									
S	2011	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																											
S	2011	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																											V			V																											
S	2011	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																											
S	2011	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																											V	V	V	V																											
S	2011	Aveo	Powertrain	(G)1.6L L4 LXV Engine Control Module																											V	V	V	V																											
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2011	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2011	Aveo	Chassis	Tire Pressure Monitor																																																								
S	2011	Aveo	Body	Supplemental Inflatable Restraint																																																V								
S	2011	Aveo	Body	Remote Function Actuation																																																								
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																								
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																								
S	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																								
S	2011	Sail	Powertrain	Transmission Control Module																																																								
S	2011	Sail	Chassis	Electronic Brake Control Module																																																								
S	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module													V	V	V																																									
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																									
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V		V																													
S	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																											V		V																													
S	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V		V																													
S	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																											V		V																													
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
S	2012	Aveo	Powertrain	Fuel Pump Control Module																																																										
S	2012	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	Aveo	Chassis	Electric Power Steering Control Module																																																										
S	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2012	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2012	Aveo	Body	Body Control Module Hatchback																																																										
S	2012	Aveo	Body	Body Control Module Sedan																																																										
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																	V								
S	2012	Aveo	Body	Passenger Presence Module																																																										
S	2012	Aveo	Body	Instrument Cluster																																																										
S	2012	Aveo	Body	Radio																																																										
S	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
S	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2012	Aveo	Body	Front Seat Heating Control Module																																																										
S	2012	Aveo	Body	Remote Function Actuation																																																										
S	2012	Aveo	Body	Parking Assist Control Module																																																										
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																								
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																								
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																								
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																								
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
S	2012	Sail	Powertrain	Transmission Control Module																																																								
S	2012	Sail	Chassis	Electronic Brake Control Module																																																								
S	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module													V	V	V																																									
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
S	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
S	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																										
S	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																											V			V																										
S	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																										
S	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																											V			V																										
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
S	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
S	2013	Aveo	Powertrain	Fuel Injector Control Module																																																								
S	2013	Aveo	Powertrain	Fuel Pump Control Module																																																								
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2013	Aveo	Chassis	Electric Power Steering Control Module																																																								
S	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2013	Aveo	Body	Body Control Module Hatchback																																																								
S	2013	Aveo	Body	Body Control Module Sedan																																																								
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																V								
S	2013	Aveo	Body	Passenger Presence Module																																																								
S	2013	Aveo	Body	Instrument Cluster																																																								
S	2013	Aveo	Body	Radio																																																								
S	2013	Aveo	Body	Telematics Communication Interface Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
S	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
S	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
S	2013	Aveo	Body	Front Seat Heating Control Module																																																									
S	2013	Aveo	Body	Remote Function Actuation																																																									
S	2013	Aveo	Body	Parking Assist Control Module																																																									
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																									
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																									
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																									
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																									
S	2013	Sail	Powertrain	Transmission Control Module																																																									
S	2013	Sail	Chassis	Electronic Brake Control Module																																																									
S	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																									
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																									
S	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																									
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																									
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																									
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																									
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
S	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																									
S	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
S	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																									
S	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
S	2014	Aveo	Powertrain	Chassis Control Module																																																										
S	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2014	Aveo	Chassis	Power Steering Control Module																																																										
S	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2014	Aveo	Body	Body Control Module Hatchback																																																										
S	2014	Aveo	Body	Body Control Module Sedan																																																										
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Aveo	Body	Instrument Cluster																																																										
S	2014	Aveo	Body	Radio																																																										
S	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
S	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2014	Aveo	Body	Front Seat Heating Control Module																																																										
S	2014	Aveo	Body	Keyless Entry Control Module																																																										
S	2014	Aveo	Body	Parking Assist Control Module																																																										
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2014	Sail	Powertrain	Transmission Control Module																																																										
S	2014	Sail	Chassis	Electronic Brake Control Module																																																										
S	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
S	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
S	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
S	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
S	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
S	2015	Aveo	Powertrain	Chassis Control Module																																																										
S	2015	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2015	Aveo	Chassis	Power Steering Control Module																																																										
S	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	Aveo	Body	Body Control Module Hatchback																																																										
S	2015	Aveo	Body	Body Control Module Sedan																																																										
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Aveo	Body	Instrument Cluster																																																										
S	2015	Aveo	Body	Radio																																																										
S	2015	Aveo	Body	Telematics Communication Interface Control Module																																																										
S	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2015	Aveo	Body	Front Seat Heating Control Module																																																										
S	2015	Aveo	Body	Keyless Entry Control Module																																																										
S	2015	Aveo	Body	Parking Assist Control Module																																																										
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2015	Sail	Powertrain	Transmission Control Module																																																										
S	2015	Sail	Chassis	Electronic Brake Control Module																																																										
S	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
S	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
S	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
S	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
S	2016	Aveo	Powertrain	Chassis Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Power Steering Control Module																																																										
S	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	Aveo	Body	Body Control Module Hatchback																																																										
S	2016	Aveo	Body	Body Control Module Sedan																																																										
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Body	Instrument Cluster																																																										
S	2016	Aveo	Body	Radio																																																										
S	2016	Aveo	Body	Telematics Communication Interface Control Module																																																										
S	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2016	Aveo	Body	Front Seat Heating Control Module																																																										
S	2016	Aveo	Body	Parking Assist Control Module																																																										
S	2016	Aveo	Body	Keyless Entry Control Module																																																										
S	2016	Aveo	Body	Frontview Camera Module																																																										
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																									
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																									
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																									
S	2016	Sail	Powertrain	Transmission Control Module																																																									
S	2016	Sail	Chassis	Electronic Brake Control Module																																																									
S	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2004	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module													V	V	V																																										
T	2004	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																												
T	2004	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																											V			V																												
T	2004	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																												
T	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																											V			V																												
T	2004	ALL	Powertrain	Transmission Control Module																																																									
T	2004	ALL	Chassis	Electronic Brake Control Module																																																									
T	2004	ALL	Chassis	Electronic Brake Control Module																																																									
T	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2004	ALL	Body	Remote Function Actuation																																																									
T	2005	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module													V	V	V																																										
T	2005	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																												
T	2005	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																											V			V																												
T	2005	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																												
T	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																											V			V																												
T	2005	ALL	Powertrain	Transmission Control Module																																																									
T	2005	ALL	Chassis	Electronic Brake Control Module																																																									
T	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2005	ALL	Body	Remote Function Actuation																																																									
T	2006	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module													V	V	V																																										
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																												
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																											V			V																												
T	2006	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																											V			V																												
T	2006	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																												
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																											V			V																												
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																											V			V																												
T	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2006	ALL	Chassis	Electronic Brake Control Module																																																									
T	2006	ALL	Body	Supplemental Inflatable Restraint																																																	V								
T	2006	ALL	Body	Remote Function Actuation																																																									
T	2007	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module													V	V	V																																										
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																												
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																											V			V																												
T	2007	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																											V			V																												
T	2007	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																												
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																											V			V																												
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																											V			V																												
T	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																									
T	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2007	ALL	Chassis	Electronic Brake Control Module																																																									
T	2007	ALL	Body	Supplemental Inflatable Restraint																																																	V								
T	2007	ALL	Body	Remote Function Actuation																																																									
T	2008	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module													V	V	V																																										
T	2008	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module													V	V	V																																										
T	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																											V			V																												

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2008	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																											V			V																												
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																											V			V																												
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																											V			V																												
T	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																											V			V																												
T	2008	ALL	Powertrain	Transmission Control Module																																																									
T	2008	ALL	Powertrain	Transmission Control Module																																																									
T	2008	ALL	Chassis	Electronic Brake Control Module																																																									
T	2008	ALL	Chassis	Tire Pressure Monitor																																																									
T	2008	ALL	Body	Supplemental Inflatable Restraint																																																	V								
T	2008	ALL	Body	Remote Function Actuation																																																									
T	2008	ALL	Body	Passenger Presence System																																					V																				
T	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																											V			V																												
T	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																											V			V																												
T	2009	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																											V	V	V	V																												
T	2009	ALL	Powertrain	Transmission Control Module																																																									
T	2009	ALL	Powertrain	Transmission Control Module																																																									
T	2009	ALL	Chassis	Electronic Brake Control Module																																																									
T	2009	ALL	Chassis	Tire Pressure Monitor																																																									
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																	V								
T	2009	ALL	Body	Supplemental Inflatable Restraint																																					V																				V
T	2009	ALL	Body	Instrument Panel Cluster																																					V		V																		
T	2009	ALL	Body	Passenger Presence System																																					V																				
T	2009	ALL	Body	Theft Deterrent Module																																																								
T	2009	ALL	Body	Radio																																																								
T	2009	ALL	Body	Remote Function Actuation																																																								
T	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																											V			V																												
T	2010	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																											V			V																												
T	2010	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																											V	V	V	V																												
T	2010	ALL	Powertrain	Transmission Control Module																																																									
T	2010	ALL	Powertrain	Transmission Control Module																																																									
T	2010	ALL	Chassis	Electronic Brake Control Module																																																									
T	2010	ALL	Chassis	Tire Pressure Monitor																																																									
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																	V								
T	2010	ALL	Body	Supplemental Inflatable Restraint																																					V																				V
T	2010	ALL	Body	Instrument Panel Cluster																																					V		V																		
T	2010	ALL	Body	Passenger Presence System																																					V																				
T	2010	ALL	Body	Theft Deterrent Module																																																								
T	2010	ALL	Body	Radio																																																								
T	2010	ALL	Body	Remote Function Actuation																																																								
T	2011	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module													V	V	V																																									
T	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																												
T	2011	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																											V			V																												
T	2011	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																												
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																											V			V																												
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module Argentia																											V			V																												
T	2011	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																											V	V	V	V																												
T	2011	ALL	Powertrain	(G)1.6L L4 LXV Engine Control Module																											V	V	V	V																												
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2011	ALL	Chassis	Electronic Brake Control Module																																																									
T	2011	ALL	Chassis	Tire Pressure Monitor																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																V							
T	2011	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
T	2011	ALL	Body	Instrument Panel Cluster																																					V		V																
T	2011	ALL	Body	Passenger Presence System																																					V																		
T	2011	ALL	Body	Theft Deterrent Module																																																						
T	2011	ALL	Body	Radio																																																						
T	2011	ALL	Body	Remote Function Actuation																																																						
T	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module													V	V	V																																							
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																						
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																						
T	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																						
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																						
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																						
T	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																						
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																						
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																						
T	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																						
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																						
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																						
T	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																						
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																						
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																						
T	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																						
T	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																									
T	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																											V			V																									
T	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																									
T	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																											V			V																									
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																					
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																					
T	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																					
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																					
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																					
T	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																					
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																					
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																					
T	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																					
T	2012	Aveo	Powertrain	Fuel Injector Control Module																																																					
T	2012	Aveo	Powertrain	Fuel Pump Control Module																																																					
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																					
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																					
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																					
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																					
T	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																					
T	2012	Aveo	Chassis	Electric Power Steering Control Module																																																					
T	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																					
T	2012	Aveo	Chassis	Tire Pressure Monitor																																																					
T	2012	Aveo	Body	Body Control Module Hatchback																																																					
T	2012	Aveo	Body	Body Control Module Sedan																																																					
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																					
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																V							
T	2012	Aveo	Body	Passenger Presence Module																																																					

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2012	Aveo	Body	Instrument Cluster																																																									
T	2012	Aveo	Body	Radio																																																									
T	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																									
T	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
T	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
T	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
T	2012	Aveo	Body	Front Seat Heating Control Module																																																									
T	2012	Aveo	Body	Remote Function Actuation																																																									
T	2012	Aveo	Body	Parking Assist Control Module																																																									
T	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module													V	V	V																																										
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
T	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																											V			V																											
T	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																											V			V																											
T	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																											V			V																											
T	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																											V			V																											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
T	2013	Aveo	Powertrain	Fuel Injector Control Module																																																									
T	2013	Aveo	Powertrain	Fuel Pump Control Module																																																									
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2013	Aveo	Chassis	Electric Power Steering Control Module																																																									
T	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2013	Aveo	Body	Body Control Module Hatchback																																																									
T	2013	Aveo	Body	Body Control Module Sedan																																																									
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																	V								
T	2013	Aveo	Body	Passenger Presence Module																																																									
T	2013	Aveo	Body	Instrument Cluster																																																									
T	2013	Aveo	Body	Radio																																																									
T	2013	Aveo	Body	Telematics Communication Interface Control Module																																																									
T	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
T	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
T	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2013	Aveo	Body	Front Seat Heating Control Module																																																							
T	2013	Aveo	Body	Remote Function Actuation																																																							
T	2013	Aveo	Body	Parking Assist Control Module																																																						
T	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																						
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																						
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																						
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																						
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																						
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																						
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																						
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																						
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																						
T	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																						
T	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																						
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																						
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																						
T	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																						
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																						
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																						
T	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																						
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																						
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																						
T	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																						
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																						
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																						
T	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																						
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																						
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																						
T	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																						
T	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																						
T	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																						
T	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																						
T	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																						
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																						
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																						
T	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																						
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																						
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																						
T	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																						
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																						
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																						
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																						
T	2014	Aveo	Powertrain	Chassis Control Module																																																						
T	2014	Aveo	Powertrain	Fuel Injector Control Module																																																						
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																						
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																						
T	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																						
T	2014	Aveo	Chassis	Power Steering Control Module																																																						
T	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																						
T	2014	Aveo	Body	Body Control Module Hatchback																																																						
T	2014	Aveo	Body	Body Control Module Sedan																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
T	2014	Aveo	Body	Instrument Cluster																																																							
T	2014	Aveo	Body	Radio																																																							
T	2014	Aveo	Body	Telematics Communication Interface Control Module																																																							
T	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																							
T	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																							
T	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																							
T	2014	Aveo	Body	Front Seat Heating Control Module																																																							
T	2014	Aveo	Body	Keyless Entry Control Module																																																							
T	2014	Aveo	Body	Parking Assist Control Module																																																							
T	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																							
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																							
T	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																							
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																							
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																							
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																							
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																							
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																							
T	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																							
T	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																							
T	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																							
T	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																							
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																							
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																							
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																							
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																							
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																							
T	2015	Aveo	Powertrain	Chassis Control Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2015	Aveo	Powertrain	Fuel Injector Control Module																																																							
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																							
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																						
T	2015	Aveo	Chassis	Power Steering Control Module																																																						
T	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																						
T	2015	Aveo	Body	Body Control Module Hatchback																																																						
T	2015	Aveo	Body	Body Control Module Sedan																																																						
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
T	2015	Aveo	Body	Instrument Cluster																																																						
T	2015	Aveo	Body	Radio																																																						
T	2015	Aveo	Body	Telematics Communication Interface Control Module																																																						
T	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																						
T	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																						
T	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																						
T	2015	Aveo	Body	Front Seat Heating Control Module																																																						
T	2015	Aveo	Body	Keyless Entry Control Module																																																						
T	2015	Aveo	Body	Parking Assist Control Module																																																						
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																						
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																						
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																						
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																						
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																						
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																						
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																						
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																						
T	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																						
T	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																						
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																						
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																						
T	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																						
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																						
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																						
T	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																						
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																						
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																						
T	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																						
T	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																						
T	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																						
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																						
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																						
T	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																						
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																						
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																						
T	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																						
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																						
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																						
T	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																						
T	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																						
T	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																						
T	2016	Aveo	Powertrain	Chassis Control Module																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2016	Aveo	Chassis	Power Steering Control Module																																																										
T	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2016	Aveo	Body	Body Control Module Hatchback																																																										
T	2016	Aveo	Body	Body Control Module Sedan																																																										
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Aveo	Body	Instrument Cluster																																																										
T	2016	Aveo	Body	Radio																																																										
T	2016	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2016	Aveo	Body	Front Seat Heating Control Module																																																										
T	2016	Aveo	Body	Parking Assist Control Module																																																										
T	2016	Aveo	Body	Keyless Entry Control Module																																																										
T	2016	Aveo	Body	Frontview Camera Module																																																										
U	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																										
U	2004	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module													V	V	V																																										
U	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																												V			V																												
U	2004	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
U	2004	ALL	Powertrain	MFA Transmission Control Module 4 Speed																											V																															
U	2004	ALL	Chassis	Electronic Brake Control Module																																																										
U	2004	ALL	Chassis	Electronic Brake Control Module																																																										
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																	V								
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2004	ALL	Body	Remote Function Actuation																																																										
U	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V																																											
U	2005	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module													V	V																																											
U	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																												V			V																												
U	2005	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
U	2005	ALL	Powertrain	MFA Transmission Control Module 4 Speed																											V																															
U	2005	ALL	Chassis	Electronic Brake Control Module																																																										
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																	V								
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2005	ALL	Body	Remote Function Actuation																																																										
U	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																										
U	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																												V			V																												
U	2006	ALL	Powertrain	Transmission Control Module																											V																															
U	2006	ALL	Chassis	Electronic Brake Control Module																																																										
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																	V								
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2006	ALL	Body	Remote Function Actuation																																																										
U	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																										
U	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																												V			V																												
U	2007	ALL	Powertrain	Transmission Control Module																											V																															
U	2007	ALL	Chassis	Electronic Brake Control Module																																																										
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
U	2007	ALL	Body	Remote Function Actuation																																																								
U	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module													V	V	V																																									
U	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module													V	V	V																																									
U	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																											
U	2008	ALL	Powertrain	Transmission Control Module																										V																															
U	2008	ALL	Chassis	Electronic Brake Control Module																																																								
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2008	ALL	Body	Remote Function Actuation																																																								
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
U	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																								
U	2010	Sail	Powertrain	Transmission Control Module																																																								
U	2010	Sail	Chassis	Electronic Brake Control Module																																																								
U	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																								
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																								
U	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																								
U	2011	Sail	Powertrain	Transmission Control Module																																																								
U	2011	Sail	Chassis	Electronic Brake Control Module																																																								
U	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																								
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																								
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																								
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																								
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
U	2012	Sail	Powertrain	Transmission Control Module																																																								
U	2012	Sail	Chassis	Electronic Brake Control Module																																																								
U	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
U	2013	Sail	Powertrain	Transmission Control Module																																																								
U	2013	Sail	Chassis	Electronic Brake Control Module																																																								
U	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
U	2014	Sail	Powertrain	Transmission Control Module																																																								
U	2014	Sail	Chassis	Electronic Brake Control Module																																																								
U	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																									
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
U	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																										
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
U	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																										
U	2015	Sail	Powertrain	Transmission Control Module																																																										
U	2015	Sail	Chassis	Electronic Brake Control Module																																																										
U	2015	Sail	Chassis	Electronic Brake Control Module																																																										
U	2015	Sail	Chassis	Power Steering Control Module																																																										
U	2015	Sail	Body	Body Control Module																																																										
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
U	2015	Sail	Body	Radio/HVAC Control																																																										
U	2015	Sail	Body	HVAC Control Module																																																										
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
U	2016	Sail	Powertrain	1.2L LMU Transmission Control Module																																																										
U	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																										
U	2016	Sail	Powertrain	1.3L LDV Transmission Control Module																																																										
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
U	2016	Sail	Powertrain	1.4L LCU Transmission Control Module																																																										
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
U	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																										
U	2016	Sail	Chassis	Electronic Brake Control Module																																																										
U	2016	Sail	Chassis	Electronic Brake Control Module																																																										
U	2016	Sail	Chassis	Power Steering Control Module																																																										
U	2016	Sail	Body	Body Control Module																																																										
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
U	2016	Sail	Body	Radio/HVAC Control																																																										
U	2016	Sail	Body	Radio																																																										
U	2016	Sail	Body	HVAC Control Module																																																										
V	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																												
V	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2004	ALL	Powertrain	Transmission Control Module 4 Speed																										V																																
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																										
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																										
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2004	ALL	Body	ISU																																										V																
V	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																												
V	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2005	ALL	Powertrain	Transmission Control Module 4 Speed																										V																																
V	2005	ALL	Chassis	Electronic Brake Control Module																																																										
V	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2005	ALL	Body	ISU																																									V																
V	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																											V			V																												
V	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
V	2006	ALL	Powertrain	Transmission Control Module 4 Speed																										V																														
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																								
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																								
V	2006	ALL	Body	Supplemental Inflatable Restraint																																															V								
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2006	ALL	Body	ISU																																									V														
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module													V	V	V																																									
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector Control Module																																																								
V	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																											V		V																												
V	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																											V		V																												
V	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module													V	V	V																																									
V	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module													V	V	V																																									
V	2007	ALL	Powertrain	Transmission Control Module 4 Speed																										V																														
V	2007	ALL	Powertrain	Transmission Control Module 5 Speed																										V																														
V	2007	ALL	Chassis	Electronic Brake Control Module																																																								
V	2007	ALL	Body	Supplemental Inflatable Restraint																																															V								
V	2007	ALL	Body	ISU																																									V														
V	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																											V																														
V	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																											V																														
V	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																	V																								
V	2008	ALL	Chassis	Electronic Brake Control Module																																																								
V	2008	ALL	Body	Supplemental Inflatable Restraint																																															V								
V	2008	ALL	Body	ISU																																									V														
V	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																											V																														
V	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																											V																														
V	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
V	2009	ALL	Chassis	Electronic Brake Control Module																																																								
V	2009	ALL	Body	ISU																																									V														
V	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																											V		V																												
V	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																											V																														
V	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																											V																														
V	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																	V																								
V	2010	ALL	Chassis	Electronic Brake Control Module																																																								
V	2010	ALL	Body	ISU																																									V														
V	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																											V		V																												
V	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																											V																														
V	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																											V																														
V	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
V	2011	ALL	Chassis	Electronic Brake Control Module																																																								
V	2011	ALL	Body	ISU																																									V														
W	2004	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module													V	V																																										
W	2004	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module													V	V																																										
W	2004	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module													V	V																																										
W	2004	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V																																
W	2004	ALL	Body	Body Control Module																																					V	V	V								V								
W	2004	ALL	Body	Digital Radio Receiver																																																								
W	2004	ALL	Body	Driver Information Center																																																							
W	2004	ALL	Body	Heating and Air Conditioning																																																							
W	2004	ALL	Body	Instrument Panel Cluster																																					V	V									V								
W	2004	ALL	Body	Personalization																																													V								
W	2004	ALL	Body	Radio																																															V							V

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
W	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module													V	V																																										
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module													V	V																																										
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module													V	V																																										
W	2005	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V																															
W	2005	ALL	Body	Body Control Module																																					V	V	V								V									
W	2005	ALL	Body	Digital Radio Receiver																																																								
W	2005	ALL	Body	Driver Information Center																																																								
W	2005	ALL	Body	Heating and Air Conditioning																																																								
W	2005	ALL	Body	Instrument Panel Cluster																																					V	V										V								
W	2005	ALL	Body	Personalization																																															V									
W	2005	ALL	Body	Radio																																																V							V	
W	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																								
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																								
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																												V			V	V																								
W	2006	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V																							
W	2006	ALL	Chassis	Anti-lock Brake System																																																								
W	2006	ALL	Body	Digital Radio Receiver																																																								
W	2006	ALL	Body	Radio																																																								
W	2006	ALL	Body	Instrument Panel Cluster																																																								
W	2006	ALL	Body	Seat																																																								
W	2006	ALL	Body	Theft Deterrent Module																																																								
W	2006	ALL	Body	Body Control Module			V																																			V	V																	
W	2006	ALL	Body	HVAC C67 Single																																									V															
W	2006	ALL	Body	HVAC CJ3 Dual																																							V		V															
W	2006	ALL	Body	Remote Control Door Lock Receiver																																																								
W	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
W	2006	ALL	Body	Passenger Presence System																																					V																			
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																											V		V	V																										
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																											V		V	V																										
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																											V		V	V																										
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module																											V		V	V																										
W	2007	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V																							
W	2007	ALL	Chassis	Electronic Brake Control Module																																																								
W	2007	ALL	Body	Body Control Module			V																																			V	V																	
W	2007	ALL	Body	Digital Radio Receiver																																																								
W	2007	ALL	Body	Heated Seat Module																																																								
W	2007	ALL	Body	HVAC C67 Single																																								V																
W	2007	ALL	Body	HVAC CJ3 Dual																																							V		V															
W	2007	ALL	Body	Instrument Panel Cluster																																																								
W	2007	ALL	Body	Passenger Presence System																																					V																			
W	2007	ALL	Body	Radio																																																								
W	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
W	2007	ALL	Body	Theft Deterrent Module																																																								
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																											V		V	V																										
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																											V		V	V																										
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module																											V		V	V																										
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																											V		V	V																										
W	2008	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
W	2008	ALL	Chassis	Electronic Brake Control Module																																			V																				
W	2008	ALL	Body	Body Control Module			V																																			V	V																
W	2008	ALL	Body	Digital Radio Receiver																																																						
W	2008	ALL	Body	Heated Seat Module																																																						
W	2008	ALL	Body	HVAC C67 Single																																							V																
W	2008	ALL	Body	HVAC CJ3 Dual																																						V		V																
W	2008	ALL	Body	Instrument Panel Cluster																																																						
W	2008	ALL	Body	Passenger Presence System																																					V																		
W	2008	ALL	Body	Radio																																																							
W	2008	ALL	Body	Remote Control Door Lock Receiver																																																						
W	2008	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
W	2008	ALL	Body	Theft Deterrent Module																																																						
W	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																											V		V	V																										
W	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																											V		V	V																										
W	2009	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																											V		V	V																										
W	2009	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																											V		V	V																										
W	2009	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V																							
W	2009	ALL	Chassis	Electronic Brake Control Module																																			V																				
W	2009	ALL	Body	Body Control Module			V																																			V	V																
W	2009	ALL	Body	Digital Radio Receiver																																																						
W	2009	ALL	Body	Heated Seat Module																																																						
W	2009	ALL	Body	HVAC C67 Single																																							V																
W	2009	ALL	Body	HVAC CJ3 Dual																																						V		V																
W	2009	ALL	Body	Instrument Panel Cluster																																																						
W	2009	ALL	Body	Passenger Presence System																																					V																		
W	2009	ALL	Body	Radio																																																						
W	2009	ALL	Body	Remote Control Door Lock Receiver																																																						
W	2009	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
W	2009	ALL	Body	Theft Deterrent Module																																																						
W	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																											V		V	V																										
W	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																											V		V	V																										
W	2010	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																											V		V	V																										
W	2010	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V																							
W	2010	ALL	Chassis	Electronic Brake Control Module																																			V																				
W	2010	ALL	Body	Body Control Module			V																																			V	V																
W	2010	ALL	Body	Digital Radio Receiver																																																						
W	2010	ALL	Body	Heated Seat Module																																																						
W	2010	ALL	Body	HVAC C67 Single																																							V																
W	2010	ALL	Body	HVAC CJ3 Dual																																						V		V																
W	2010	ALL	Body	Instrument Panel Cluster																																																						
W	2010	ALL	Body	Passenger Presence System																																					V																		
W	2010	ALL	Body	Radio																																																						
W	2010	ALL	Body	Remote Control Door Lock Receiver																																																						
W	2010	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
W	2010	ALL	Body	Theft Deterrent Module																																																						
W	2011	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																											V		V	V																										
W	2011	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																											V		V	V																										
W	2011	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V																							
W	2011	ALL	Chassis	Electronic Brake Control Module																																			V																				
W	2011	ALL	Body	Body Control Module			V																																			V	V																
W	2011	ALL	Body	Digital Radio Receiver																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
W	2011	ALL	Body	Heated Seat Module																																																								
W	2011	ALL	Body	HVAC C67 Single																																							V																
W	2011	ALL	Body	HVAC CJ3 Dual																																						V		V																
W	2011	ALL	Body	Instrument Panel Cluster																																																							
W	2011	ALL	Body	Passenger Presence System																																					V																			
W	2011	ALL	Body	Radio																																																								
W	2011	ALL	Body	Remote Control Door Lock Receiver																																																								
W	2011	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
W	2011	ALL	Body	Theft Deterrent Module																																																								
W	2012	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																												V	V	V																											
W	2012	ALL	Powertrain	Transmission Control Module																																	V	V																						
W	2012	ALL	Powertrain	Fuel Pump Control Module																																																								
W	2012	ALL	Chassis	Electronic Brake Control Module																																			V																					
W	2012	ALL	Body	Body Control Module			V																																			V	V																	
W	2012	ALL	Body	Digital Radio Receiver																																																								
W	2012	ALL	Body	Heated Seat Module																																																								
W	2012	ALL	Body	HVAC C67 Single																																								V																
W	2012	ALL	Body	HVAC CJ3 Dual																																						V		V																
W	2012	ALL	Body	Instrument Panel Cluster																																																								
W	2012	ALL	Body	Passenger Presence System																																					V																			
W	2012	ALL	Body	Radio																																																								
W	2012	ALL	Body	Remote Control Door Lock Receiver																																																								
W	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
W	2012	ALL	Body	Theft Deterrent Module																																																								
W	2013	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																											V	V	V	V																											
W	2013	ALL	Powertrain	Transmission Control Module																																	V	V																						
W	2013	ALL	Powertrain	Fuel Pump Control Module																																																								
W	2013	ALL	Chassis	Electronic Brake Control Module																																			V																					
W	2013	ALL	Body	Body Control Module			V																																			V	V																	
W	2013	ALL	Body	Digital Radio Receiver																																																								
W	2013	ALL	Body	Heated Seat Module																																																								
W	2013	ALL	Body	HVAC C67 Single																																								V																
W	2013	ALL	Body	HVAC CJ3 Dual																																						V		V																
W	2013	ALL	Body	Instrument Panel Cluster																																																								
W	2013	ALL	Body	Passenger Presence System																																					V																			
W	2013	ALL	Body	Radio																																																								
W	2013	ALL	Body	Remote Control Door Lock Receiver																																																								
W	2013	ALL	Body	Supplemental Inflatable Restraint																																																								
W	2013	ALL	Body	Theft Deterrent Module																																																								
W	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
W	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
W	2014	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																								
W	2014	Impala	Chassis	Electronic Brake Control Module																																																								
W	2014	Impala	Body	Body Control Module																																																								
W	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
W	2014	Impala	Body	Passenger Presence Module																																																								
W	2014	Impala	Body	Instrument Cluster																																																								
W	2014	Impala	Body	Radio																																																								
W	2014	Impala	Body	Digital Radio Receiver Control Module																																																								
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																								
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
W	2014	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
W	2014	Impala	Body	HVAC Manual Control Single Zone (C67)																																																										
W	2014	Impala	Body	Front Seat Heating Control Module																																																										
W	2014	Impala	Body	Remote Control Door Lock Receiver																																																										
W	2014	Impala	Body	Theft Deterrent Module																																																										
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
W	2014	Lumina	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
W	2014	Lumina	Powertrain	Fuel Injector Control Module																																																										
W	2014	Lumina	Powertrain	Chassis Control Module																																																										
W	2014	Lumina	Chassis	Electronic Brake Control Module																																																										
W	2014	Lumina	Chassis	Parking Brake Control Module																																																										
W	2014	Lumina	Chassis	Power Steering Control Module																																																										
W	2014	Lumina	Chassis	Steering Wheel Angle Sensor Module																																																										
W	2014	Lumina	Chassis	Suspension Control Module																																																										
W	2014	Lumina	Body	Body Control Module Coupe																																																										
W	2014	Lumina	Body	Body Control Module Sedan																																																										
W	2014	Lumina	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2014	Lumina	Body	Instrument Cluster																																																										
W	2014	Lumina	Body	Head-Up Display Module																																																										
W	2014	Lumina	Body	Radio Control																																																										
W	2014	Lumina	Body	HVAC Control																																																										
W	2014	Lumina	Body	Headlamp Control Module																																																										
W	2014	Lumina	Body	Trailer Interface Control Module																																																										
W	2014	Lumina	Body	Radio																																																										
W	2014	Lumina	Body	HVAC Control Module																																																										
W	2014	Lumina	Body	Keyless Entry Control Module																																																										
W	2014	Lumina	Body	Right Side Object Detection Control Module																																																										
W	2014	Lumina	Body	Left Side Object Detection Control Module																																																										
W	2014	Lumina	Body	Parking Assist Control Module																																																										
W	2014	Lumina	Body	Frontview Camera Module																																																										
W	2014	Lumina	Body	Steering Column Lock Control Module																																																										
W	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
W	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
W	2015	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
W	2015	Impala	Chassis	Electronic Brake Control Module																																																										
W	2015	Impala	Body	Body Control Module																																																										
W	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2015	Impala	Body	Passenger Presence Module																																																										
W	2015	Impala	Body	Instrument Cluster																																																										
W	2015	Impala	Body	Radio																																																										
W	2015	Impala	Body	Digital Radio Receiver Control Module																																																										
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 9																																																										
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 10																																																										
W	2015	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
W	2015	Impala	Body	HVAC Manual Control Single Zone (C67)																																																										
W	2015	Impala	Body	Front Seat Heating Control Module																																																										
W	2015	Impala	Body	Remote Control Door Lock Receiver																																																										
W	2015	Impala	Body	Theft Deterrent Module																																																										
W	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
W	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
W	2016	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																									
W	2016	Impala	Chassis	Electronic Brake Control Module																																																										
W	2016	Impala	Body	Body Control Module																																																									
W	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2016	Impala	Body	Passenger Presence Module																																																										
W	2016	Impala	Body	Instrument Cluster																																																										
W	2016	Impala	Body	Radio																																																										
W	2016	Impala	Body	Digital Radio Receiver Control Module																																																										
W	2016	Impala	Body	Telematics Communication Interface Control Module																																																										
W	2016	Impala	Body	HVAC Manual Control Dual Zone (CJ2)																																																										
W	2016	Impala	Body	HVAC Manual Control Single Zone (C67)																																																										
W	2016	Impala	Body	Front Seat Heating Control Module																																																										
W	2016	Impala	Body	Remote Control Door Lock Receiver																																																										
W	2016	Impala	Body	Theft Deterrent Module																																																										
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Auto													V	V	V																																										
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Manual													V	V	V																																										
Y	2004	ALL	Powertrain	(S)5.7L V8 LS6 Engine Control Module													V	V	V																																										
Y	2004	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V																																			
Y	2004	ALL	Chassis	RTD																																																										
Y	2004	ALL	Body	Body Control Module																																					V																					
Y	2004	ALL	Body	Heating and Air Conditioning																																					V																					
Y	2004	ALL	Body	Instrument Panel Cluster																																						V																				
Y	2004	ALL	Body	Left Door Control Module																																					V	V	V										V									
Y	2004	ALL	Body	Radio																																																									
Y	2004	ALL	Body	Remote Function Actuation																																													V		V									
Y	2004	ALL	Body	Right Door Control Module																																					V	V	V								V									
Y	2004	ALL	Body	Seat Control Module																																						V	V									V									
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																					V	V																		
Y	2005	ALL	Powertrain	Engine Control Module																											V		V	V	V																											
Y	2005	ALL	Powertrain	Transmission Control Module																V	V	V		V													V																								
Y	2005	ALL	Chassis	Electronic Brake Control Module																																			V																						
Y	2005	ALL	Chassis	Electronic Suspension Control																																																										
Y	2005	ALL	Chassis	Steering Wheel and Column																																																										
Y	2005	ALL	Body	Amplifier																																																									
Y	2005	ALL	Body	Body Control Module																																									V																
Y	2005	ALL	Body	Digital Radio Receiver																																																										
Y	2005	ALL	Body	Driver Door Module																																																										
Y	2005	ALL	Body	Driver Door Switch																																																										
Y	2005	ALL	Body	Driver Position Module																																						V	V																			
Y	2005	ALL	Body	Folding Top Module																																						V	V																			
Y	2005	ALL	Body	Head Up Display																																																										
Y	2005	ALL	Body	HVAC Control Module																																													V												
Y	2005	ALL	Body	Instrument Panel Cluster																																																										
Y	2005	ALL	Body	Navigation Radio																																																										V
Y	2005	ALL	Body	Passenger Door Module																																																										
Y	2005	ALL	Body	Radio																																																										
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																					V																					
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																					V																					V
Y	2006	ALL	Powertrain	Engine Control Module																											V		V	V	V																											
Y	2006	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2006	ALL	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Y	2006	ALL	Chassis	Electronic Brake Control Module																																			V																				
Y	2006	ALL	Chassis	Electronic Suspension Control																																																							
Y	2006	ALL	Chassis	Steering Wheel and Column																																																							
Y	2006	ALL	Body	Body Control Module																																									V													
Y	2006	ALL	Body	CD Changer																																																						
Y	2006	ALL	Body	Digital Radio Receiver																																																						
Y	2006	ALL	Body	Driver Door Module																																																						
Y	2006	ALL	Body	Driver Door Switch																																																						
Y	2006	ALL	Body	Driver Position Module																																						V	V																
Y	2006	ALL	Body	Folding Top Module																																						V	V																
Y	2006	ALL	Body	Head Up Display																																																						
Y	2006	ALL	Body	HVAC Control Module																																																						
Y	2006	ALL	Body	Instrument Panel Cluster																																																						
Y	2006	ALL	Body	Navigation Radio																																																						V
Y	2006	ALL	Body	Passenger Door Module																																																						
Y	2006	ALL	Body	Radio																																																						
Y	2006	ALL	Body	Remote Control Door Lock Receiver																																					V																		
Y	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
Y	2007	ALL	Powertrain	Engine Control Module																											V		V	V	V																								
Y	2007	ALL	Powertrain	Exhaust Flow Control Module																																																						
Y	2007	ALL	Powertrain	Transmission Control Module																																V	V																						
Y	2007	ALL	Chassis	Electronic Brake Control Module																																			V																			
Y	2007	ALL	Chassis	Electronic Suspension Control																																																						
Y	2007	ALL	Body	Body Control Module																																									V													
Y	2007	ALL	Body	CD Changer																																																						
Y	2007	ALL	Body	Digital Radio Receiver																																																						
Y	2007	ALL	Body	Driver Door Module																																																						
Y	2007	ALL	Body	Driver Door Switch																																																						
Y	2007	ALL	Body	Driver Position Module																																						V	V																
Y	2007	ALL	Body	Folding Top Module																																						V	V																
Y	2007	ALL	Body	Head Up Display																																																						
Y	2007	ALL	Body	HVAC Control Module																																																						
Y	2007	ALL	Body	Instrument Panel Cluster																																																						
Y	2007	ALL	Body	Navigation Radio																																																						V
Y	2007	ALL	Body	Passenger Door Module																																																						
Y	2007	ALL	Body	Radio																																																						
Y	2007	ALL	Body	Remote Control Door Lock Receiver																																					V																		
Y	2007	ALL	Body	Steering Column Lock Module																																																						
Y	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
Y	2008	ALL	Powertrain	Engine Control Module																											V	V	V	V																									
Y	2008	ALL	Powertrain	Exhaust Flow Control Module																																																						
Y	2008	ALL	Powertrain	Transmission Control Module																																V	V																						
Y	2008	ALL	Chassis	Electronic Brake Control Module																																			V																		
Y	2008	ALL	Chassis	Electronic Suspension Control																																																						
Y	2008	ALL	Body	Body Control Module																																									V													
Y	2008	ALL	Body	CD Changer																																																						
Y	2008	ALL	Body	Digital Radio Receiver																																																						
Y	2008	ALL	Body	Driver Door Module																																																						
Y	2008	ALL	Body	Driver Door Switch																																																						
Y	2008	ALL	Body	Driver Position Module																																						V	V																
Y	2008	ALL	Body	Folding Top Module																																						V	V																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Y	2008	ALL	Body	Head Up Display																																																								
Y	2008	ALL	Body	HVAC Control Module																																																								
Y	2008	ALL	Body	Instrument Panel Cluster																																																								
Y	2008	ALL	Body	Navigation Radio																																																								V
Y	2008	ALL	Body	Passenger Door Module																																																								
Y	2008	ALL	Body	Radio																																																								
Y	2008	ALL	Body	Personal Audio Link Module																																																								
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																					V																			
Y	2008	ALL	Body	Steering Column Lock Module																																																								
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																											V		V	V																										
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																								
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																V	V																							
Y	2009	ALL	Chassis	Electronic Brake Control Module																																			V																					
Y	2009	ALL	Chassis	Electronic Suspension Control																																																								
Y	2009	ALL	Body	Body Control Module																																									V															
Y	2009	ALL	Body	CD Changer																																																								
Y	2009	ALL	Body	Digital Radio Receiver																																																								
Y	2009	ALL	Body	Driver Door Module																																																								
Y	2009	ALL	Body	Driver Door Switch																																																								
Y	2009	ALL	Body	Driver Position Module																																						V	V																	
Y	2009	ALL	Body	Folding Top Module																																						V	V																	
Y	2009	ALL	Body	Head Up Display																																																								
Y	2009	ALL	Body	HVAC Control Module																																																								
Y	2009	ALL	Body	Instrument Panel Cluster																																																								
Y	2009	ALL	Body	Navigation Radio																																																								V
Y	2009	ALL	Body	Passenger Door Module																																																								
Y	2009	ALL	Body	Radio																																																								
Y	2009	ALL	Body	Personal Audio Link Module																																																								
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																					V																			
Y	2009	ALL	Body	Steering Column Lock Module																																																								
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																											V		V	V																										
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																								
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																V	V																							
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																											V		V	V																										
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																								
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																								
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																											V		V	V																										
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																								
Y	2010	ALL	Chassis	Electronic Brake Control Module																																			V																					
Y	2010	ALL	Chassis	Electronic Suspension Control																																																								
Y	2010	ALL	Body	Body Control Module																																									V															
Y	2010	ALL	Body	CD Changer																																																								
Y	2010	ALL	Body	Digital Radio Receiver																																																								
Y	2010	ALL	Body	Driver Door Module																																																								
Y	2010	ALL	Body	Driver Door Switch																																																								
Y	2010	ALL	Body	Driver Position Module																																						V	V																	
Y	2010	ALL	Body	Folding Top Module																																						V	V																	
Y	2010	ALL	Body	Head Up Display																																																								
Y	2010	ALL	Body	HVAC Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Y	2010	ALL	Body	Instrument Panel Cluster																																																							
Y	2010	ALL	Body	Navigation Radio																																																							V
Y	2010	ALL	Body	Passenger Door Module																																																						
Y	2010	ALL	Body	Radio																																																						
Y	2010	ALL	Body	Personal Audio Link Module																																																						
Y	2010	ALL	Body	Remote Control Door Lock Receiver																																					V																		
Y	2010	ALL	Body	Steering Column Lock Module																																																						
Y	2010	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																											V		V	V																									
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																						
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																V	V																					
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																											V		V	V																									
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																						
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																						
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																											V		V	V																									
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																						
Y	2011	ALL	Chassis	Electronic Brake Control Module																																			V																			
Y	2011	ALL	Chassis	Electronic Suspension Control																																																						
Y	2011	ALL	Body	Body Control Module																																										V												
Y	2011	ALL	Body	CD Changer																																																						
Y	2011	ALL	Body	Digital Radio Receiver																																																						
Y	2011	ALL	Body	Driver Door Module																																																						
Y	2011	ALL	Body	Driver Door Switch																																																						
Y	2011	ALL	Body	Driver Position Module																																						V	V																
Y	2011	ALL	Body	Folding Top Module																																						V	V																
Y	2011	ALL	Body	Head Up Display																																																						
Y	2011	ALL	Body	HVAC Control Module																																																						
Y	2011	ALL	Body	Instrument Panel Cluster																																																						
Y	2011	ALL	Body	Navigation Radio																																																						V
Y	2011	ALL	Body	Passenger Door Module																																																						
Y	2011	ALL	Body	Radio																																																						
Y	2011	ALL	Body	Personal Audio Link Module																																																						
Y	2011	ALL	Body	Remote Control Door Lock Receiver																																					V																		
Y	2011	ALL	Body	Steering Column Lock Module																																																						
Y	2011	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																											V		V	V																									
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																						
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																V	V																					
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																											V		V	V																									
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																						
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																						
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																											V		V	V																									
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																						
Y	2012	ALL	Chassis	Electronic Brake Control Module																																			V																			
Y	2012	ALL	Chassis	Electronic Suspension Control																																																						
Y	2012	ALL	Body	Body Control Module																																										V												
Y	2012	ALL	Body	CD Changer																																																						
Y	2012	ALL	Body	Digital Radio Receiver																																																						
Y	2012	ALL	Body	Driver Door Module																																																						
Y	2012	ALL	Body	Driver Door Switch																																																						
Y	2012	ALL	Body	Driver Position Module																																						V	V																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Y	2012	ALL	Body	Folding Top Module																																						V	V																
Y	2012	ALL	Body	Head Up Display																																																						
Y	2012	ALL	Body	HVAC Control Module																																																						
Y	2012	ALL	Body	Instrument Panel Cluster																																																						
Y	2012	ALL	Body	Navigation Radio																																																						V
Y	2012	ALL	Body	Passenger Door Module																																																						
Y	2012	ALL	Body	Radio																																																						
Y	2012	ALL	Body	Personal Audio Link Module																																																						
Y	2012	ALL	Body	Remote Control Door Lock Receiver																																					V																		
Y	2012	ALL	Body	Steering Column Lock Module																																																						
Y	2012	ALL	Body	Supplemental Inflatable Restraint																																					V																		
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																										V		V	V																										
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																						
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																V	V																						
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																										V		V	V																										
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																						
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																						
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																										V		V	V																										
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																						
Y	2013	ALL	Chassis	Electronic Brake Control Module																																		V																				
Y	2013	ALL	Chassis	Electronic Suspension Control																																																						
Y	2013	ALL	Body	Body Control Module																																									V													
Y	2013	ALL	Body	CD Changer																																																						
Y	2013	ALL	Body	Digital Radio Receiver																																																						
Y	2013	ALL	Body	Driver Door Module																																																						
Y	2013	ALL	Body	Driver Door Switch																																																						
Y	2013	ALL	Body	Driver Position Module																																						V	V																
Y	2013	ALL	Body	Folding Top Module																																						V	V																
Y	2013	ALL	Body	Head Up Display																																																						
Y	2013	ALL	Body	HVAC Control Module																																																						
Y	2013	ALL	Body	Instrument Panel Cluster																																																						
Y	2013	ALL	Body	Navigation Radio																																																						V
Y	2013	ALL	Body	Passenger Door Module																																																						
Y	2013	ALL	Body	Radio																																																						
Y	2013	ALL	Body	Personal Audio Link Module																																																						
Y	2013	ALL	Body	Remote Control Door Lock Receiver																																					V																		
Y	2013	ALL	Body	Steering Column Lock Module																																																						
Y	2013	ALL	Body	Supplemental Inflatable Restraint																																					V																		
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																						
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission							V																																															
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																						
Y	2014	Corvette	Powertrain	Chassis Control Module																																																						
Y	2014	Corvette	Chassis	Electronic Brake Control Module																																																						
Y	2014	Corvette	Chassis	Parking Brake Control Module																																																						
Y	2014	Corvette	Chassis	Power Steering Control Module																																																						
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																						
Y	2014	Corvette	Chassis	Suspension Control Module																																																						
Y	2014	Corvette	Body	Body Control Module Convertible																																																						
Y	2014	Corvette	Body	Body Control Module Coupe																																																						
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
Y	2014	Corvette	Body	Passenger Presence Module																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Y	2014	Corvette	Body	Instrument Cluster																																																								
Y	2014	Corvette	Body	Radio/HVAC Control																																																								
Y	2014	Corvette	Body	Inside Rearview Mirror																																																								
Y	2014	Corvette	Body	Radio																																																								
Y	2014	Corvette	Body	Amplifier																																																								
Y	2014	Corvette	Body	Human Machine Interface Control Module																																																								
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																								
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																								
Y	2014	Corvette	Body	HVAC Control Module																																																								
Y	2014	Corvette	Body	Seat Memory Control Module - Passenger																																																								
Y	2014	Corvette	Body	Seat Memory Control Module - Driver																																																								
Y	2014	Corvette	Body	Folding Top Control Module																																																								
Y	2014	Corvette	Body	Keyless Entry Control Module																																																								
Y	2014	Corvette	Body	Steering Column Lock Control Module																																																								
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																								
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission							V																																																	
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																								
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Automatic Transmission																																																								
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Manual Transmission							V																																																	
Y	2015	Corvette	Powertrain	6.2L LT4 Transmission Control Module																																																								
Y	2015	Corvette	Powertrain	Chassis Control Module																																																								
Y	2015	Corvette	Chassis	Electronic Brake Control Module																																																								
Y	2015	Corvette	Chassis	Parking Brake Control Module																																																								
Y	2015	Corvette	Chassis	Power Steering Control Module																																																								
Y	2015	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																								
Y	2015	Corvette	Chassis	Suspension Control Module																																																								
Y	2015	Corvette	Body	Body Control Module Convertible																																																								
Y	2015	Corvette	Body	Body Control Module Coupe																																																								
Y	2015	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
Y	2015	Corvette	Body	Passenger Presence Module																																																								
Y	2015	Corvette	Body	Instrument Cluster																																																								
Y	2015	Corvette	Body	Radio/HVAC Control																																																								
Y	2015	Corvette	Body	Vehicle Performance Data Recorder																																																								
Y	2015	Corvette	Body	Inside Rearview Mirror																																																								
Y	2015	Corvette	Body	Radio																																																								
Y	2015	Corvette	Body	Amplifier																																																								
Y	2015	Corvette	Body	Human Machine Interface Control Module																																																								
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																								
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																								
Y	2015	Corvette	Body	HVAC Control Module																																																								
Y	2015	Corvette	Body	Seat Memory Control Module - Passenger																																																								
Y	2015	Corvette	Body	Seat Memory Control Module - Driver																																																								
Y	2015	Corvette	Body	Folding Top Control Module																																																								
Y	2015	Corvette	Body	Keyless Entry Control Module																																																								
Y	2015	Corvette	Body	Steering Column Lock Control Module																																																								
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																								
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission							V																																																	
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Automatic Transmission																																																								
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Manual Transmission							V																																																	
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Y	2016	Corvette	Powertrain	Rear Differential Clutch Control Module																																																									
Y	2016	Corvette	Chassis	Electronic Brake Control Module																																																										
Y	2016	Corvette	Chassis	Parking Brake Control Module																																																										
Y	2016	Corvette	Chassis	Power Steering Control Module																																																										
Y	2016	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																										
Y	2016	Corvette	Chassis	Suspension Control Module																																																										
Y	2016	Corvette	Body	Body Control Module																																																										
Y	2016	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Y	2016	Corvette	Body	Passenger Presence Module																																																										
Y	2016	Corvette	Body	Instrument Cluster																																																										
Y	2016	Corvette	Body	Radio/HVAC Control																																																										
Y	2016	Corvette	Body	Vehicle Performance Data Recorder																																																										
Y	2016	Corvette	Body	Video Processing Control Module								V	V	V	V	V																																														
Y	2016	Corvette	Body	Inside Rearview Mirror																																																										
Y	2016	Corvette	Body	Radio																																																										
Y	2016	Corvette	Body	Amplifier																																																										
Y	2016	Corvette	Body	Human Machine Interface Control Module																																																										
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2016	Corvette	Body	HVAC Control Module																																																										
Y	2016	Corvette	Body	Liftgate Control Module																																																										
Y	2016	Corvette	Body	Seat Memory Control Module - Passenger																																																										
Y	2016	Corvette	Body	Seat Memory Control Module - Driver																																																										
Y	2016	Corvette	Body	Folding Top Control Module																																																										
Y	2016	Corvette	Body	Keyless Entry Control Module																																																										
Y	2016	Corvette	Body	Steering Column Lock Control Module																																																										
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																										
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																										
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																										
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																										
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																										
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																										
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																										
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																										
Y	2016	Cruze	Chassis	Electronic Brake Control Module																																																										
Y	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																										
Y	2016	Cruze	Chassis	Power Steering Control Module																																																										
Y	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
Y	2016	Cruze	Body	Body Control Module																																																										
Y	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Y	2016	Cruze	Body	Passenger Presence Module																																																										
Y	2016	Cruze	Body	Instrument Cluster																																																										
Y	2016	Cruze	Body	Radio Controls																																																										
Y	2016	Cruze	Body	HVAC Controls																																																										
Y	2016	Cruze	Body	Trailer Interface Control Module																																																										
Y	2016	Cruze	Body	Radio Base (IO3 IO7)																																																										
Y	2016	Cruze	Body	Radio (IOA)																																																										
Y	2016	Cruze	Body	Radio (IOB)																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Y	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																								
Y	2016	Cruze	Body	Amplifier																																																								
Y	2016	Cruze	Body	Multimedia Player Interface Module																																																								
Y	2016	Cruze	Body	Human Machine Interface Control Module																																																								
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																								
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
Y	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
Y	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																								
Y	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																								
Y	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																								
Y	2016	Cruze	Body	Keyless Entry Control Module																																																								
Y	2016	Cruze	Body	Right Side Object Detection Control Module																																																								
Y	2016	Cruze	Body	Left Side Object Detection Control Module																																																								
Y	2016	Cruze	Body	Parking Assist Control Module																																																								
Y	2016	Cruze	Body	Frontview Camera Module																																																								
Y	2016	Cruze	Body	Steering Column Lock Control Module																																																								
Y	2016	Cruze	Body	Long Range Radar Sensor Module		V																																																							
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																V	V	V		V	V	V	V		V								V																								
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																								
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Transmission Control Module																V	V	V		V	V	V	V		V								V																								
Z	2004	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2004	ALL	Chassis	Power Steering Control Module																																																								
Z	2004	ALL	Body	Body Control Module																																									V															
Z	2004	ALL	Body	Digital Radio Receiver																																																								
Z	2004	ALL	Body	HVAC Control Module																																																								
Z	2004	ALL	Body	Instrument Panel Cluster																																																								
Z	2004	ALL	Body	Radio																																																								
Z	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2004	ALL	Body	Theft Deterrent Module																																																								
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																V	V	V		V	V	V	V		V								V																								
Z	2005	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																								
Z	2005	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2005	ALL	Chassis	Power Steering Control Module																																																								
Z	2005	ALL	Body	Body Control Module																																									V															
Z	2005	ALL	Body	Digital Radio Receiver																																																								
Z	2005	ALL	Body	HVAC Control Module																																																								
Z	2005	ALL	Body	Instrument Panel Cluster																																																								
Z	2005	ALL	Body	Radio																																																								
Z	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2005	ALL	Body	Theft Deterrent Module																																																								
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																V	V	V		V	V	V	V		V								V																								
Z	2006	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																								
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																V	V	V		V	V	V	V		V								V																								
Z	2006	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2006	ALL	Chassis	Power Steering Control Module																																																								
Z	2006	ALL	Body	Body Control Module																																									V															
Z	2006	ALL	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Z	2006	ALL	Body	HVAC Control Module																																																								
Z	2006	ALL	Body	Instrument Panel Cluster																																																								
Z	2006	ALL	Body	Radio																																																								
Z	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2006	ALL	Body	Theft Deterrent Module																																																								
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																											V	V	V	V																										
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																V	V	V		V					V								V																							
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																											V		V	V																										
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																V	V	V		V					V								V																							
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																											V		V	V																										
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																V	V	V		V	V	V	V		V								V																							
Z	2007	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2007	ALL	Chassis	Power Steering Control Module																																																								
Z	2007	ALL	Body	Body Control Module																																										V														
Z	2007	ALL	Body	Digital Radio Receiver																																																								
Z	2007	ALL	Body	Disc Player and Video Display																																																								
Z	2007	ALL	Body	HVAC Control Module																																																								
Z	2007	ALL	Body	Instrument Panel Cluster																																																								
Z	2007	ALL	Body	Radio																																																								
Z	2007	ALL	Body	Remote Control Door Lock Receiver																																																								
Z	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2007	ALL	Body	Theft Deterrent Module																																																								
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																											V	V	V	V																										
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																V	V	V		V													V																							
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																											V	V	V	V																										
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																								
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																V	V	V		V													V																							
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																											V		V	V																										
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																V	V	V		V													V																							
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																										
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																	V																							
Z	2008	ALL	Chassis	Electronic Brake Control Module																																			V																					
Z	2008	ALL	Chassis	Power Steering Control Module																																																								
Z	2008	ALL	Body	Body Control Module Classic																																										V														
Z	2008	ALL	Body	Body Control Module Malibu																																										V														
Z	2008	ALL	Body	Digital Radio Receiver																																																								
Z	2008	ALL	Body	Disc Player and Video Display																																																								
Z	2008	ALL	Body	HVAC Control Module Classic																																																								
Z	2008	ALL	Body	HVAC Control Module Malibu																																																								
Z	2008	ALL	Body	Instrument Panel Cluster Classic																																																								
Z	2008	ALL	Body	Instrument Panel Cluster Malibu																																																								
Z	2008	ALL	Body	Radio																																																								
Z	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
Z	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2008	ALL	Body	Theft Deterrent Module																																																								
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																											V		V	V																										
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																								
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																V	V	V		V	V	V	V										V																							
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump																											V		V	V																										
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump																											V		V	V																										
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift																V	V	V		V	V	V	V		V								V																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Without Tap Shift																V	V	V		V	V	V	V										V																							
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																											V		V	V																									
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																V	V	V		V	V	V	V										V																							
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																									
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																	V																							
Z	2009	ALL	Chassis	Electronic Brake Control Module																																				V																				
Z	2009	ALL	Chassis	Power Steering Control Module																																																							
Z	2009	ALL	Body	Body Control Module																																										V													
Z	2009	ALL	Body	Digital Radio Receiver																																																						
Z	2009	ALL	Body	Disc Player and Video Display																																																						
Z	2009	ALL	Body	HVAC Control Module																																																						
Z	2009	ALL	Body	Instrument Panel Cluster																																																						
Z	2009	ALL	Body	Personal Audio Link Module																																																						
Z	2009	ALL	Body	Radio																																																						
Z	2009	ALL	Body	Supplemental Inflatable Restraint																																																						
Z	2009	ALL	Body	Theft Deterrent Module																																																						
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																											V		V	V																									
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																						
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																V	V	V		V	V	V	V										V																							
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Engine Control Module																											V		V	V																									
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 6 Speed																																																						
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 4 Speed																V	V	V		V	V	V	V										V																							
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																											V		V	V																									
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																V	V	V		V	V	V	V										V																							
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																											V		V	V																									
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																V	V	V		V	V	V	V										V																							
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																									
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																	V	V																					
Z	2010	ALL	Chassis	Electronic Brake Control Module																																				V																			
Z	2010	ALL	Chassis	Power Steering Control Module																																																						
Z	2010	ALL	Body	Body Control Module																																										V													
Z	2010	ALL	Body	Digital Radio Receiver																																																						
Z	2010	ALL	Body	HVAC Control Module																																																						
Z	2010	ALL	Body	Instrument Panel Cluster																																																						
Z	2010	ALL	Body	Personal Audio Link Module																																																						
Z	2010	ALL	Body	Radio																																																						
Z	2010	ALL	Body	Supplemental Inflatable Restraint																																																						
Z	2010	ALL	Body	Theft Deterrent Module																																																						
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																											V		V	V																									
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																						
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Engine Control Module																											V		V	V																									
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																						
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																									
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																	V	V																					
Z	2011	ALL	Chassis	Electronic Brake Control Module																																				V																			
Z	2011	ALL	Chassis	Power Steering Control Module																																																						
Z	2011	ALL	Body	Body Control Module																																										V													
Z	2011	ALL	Body	Digital Radio Receiver																																																						
Z	2011	ALL	Body	HVAC Control Module																																																						
Z	2011	ALL	Body	Instrument Panel Cluster																																																						
Z	2011	ALL	Body	Personal Audio Link Module																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Z	2011	ALL	Body	Radio																																																								
Z	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2011	ALL	Body	Theft Deterrent Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Engine Control Module																											V		V	V																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Engine Control Module																											V		V	V																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Engine Control Module																											V		V	V																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																V	V																							
Z	2012	Malibu (Seventh Gen)	Chassis	Electronic Brake Control Module																																			V																					
Z	2012	Malibu (Seventh Gen)	Chassis	Power Steering Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Body	Body Control Module																																										V														
Z	2012	Malibu (Seventh Gen)	Body	Digital Radio Receiver																																																								
Z	2012	Malibu (Seventh Gen)	Body	HVAC Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Body	Instrument Panel Cluster																																																								
Z	2012	Malibu (Seventh Gen)	Body	Personal Audio Link Module																																																								
Z	2012	Malibu (Seventh Gen)	Body	Radio																																																								
Z	2012	Malibu (Seventh Gen)	Body	Supplemental Inflatable Restraint																																																								
Z	2012	Malibu (Seventh Gen)	Body	Theft Deterrent Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Fuel Injector Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Fuel Pump Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Fuel Pump Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	Rear Differential Clutch Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Electronic Brake Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Parking Brake Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Power Steering Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Steering Wheel Angle Sensor Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Suspension Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																								
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																								
Z	2012	Malibu (Eighth Gen)	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Z	2012	Malibu (Eighth Gen)	Body	Instrument Cluster																																																									
Z	2012	Malibu (Eighth Gen)	Body	Head-Up Display Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Headlamp Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Radio																																																										
Z	2012	Malibu (Eighth Gen)	Body	Digital Radio Receiver Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Multimedia Player Interface Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Mobile Telephone Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Dual (CJ2)																																																										
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Single (C68)																																																										
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Manual Single (C67)																																																										
Z	2012	Malibu (Eighth Gen)	Body	Rear Seat Heating Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Keyless Entry Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Right Side Object Detection Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Left Side Object Detection Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Parking Assist Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Vehicle Direction Camera Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Steering Column Lock Control Module																																																										
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Engine Control Module																																																										
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Transmission Control Module																																																										
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Engine Control Module																																																										
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 1																																																										
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 2																																																										
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 6 Speed (MNM)																																																										
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 8 Speed (MRC)																																																										
Z	2016	Malibu	Chassis	Electronic Brake Control Module																																																										
Z	2016	Malibu	Chassis	Brake Booster Control Module																																																										
Z	2016	Malibu	Chassis	Power Steering Control Module																																																										
Z	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
Z	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
Z	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Z	2016	Malibu	Body	Passenger Presence Module																																																										
Z	2016	Malibu	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
Z	2016	Malibu	Body	Instrument Cluster Enhanced Monochrome Driver Info Center (UDC)																																																										
Z	2016	Malibu	Body	Radio Controls																																																										
Z	2016	Malibu	Body	HVAC Controls																																																										
Z	2016	Malibu	Body	Active Safety Control Module	V																																																									
Z	2016	Malibu	Body	Headlamp Control Module																																																										
Z	2016	Malibu	Body	Radio Base																																																										
Z	2016	Malibu	Body	Radio (IOA)																																																										
Z	2016	Malibu	Body	Radio Uplevel (IO4 IO5 IO6)																																																										
Z	2016	Malibu	Body	Amplifier																																																										
Z	2016	Malibu	Body	Human Machine Interface Control Module																																																										
Z	2016	Malibu	Body	Navigation Control Module																																																										
Z	2016	Malibu	Body	Mobile Telephone Control Module																																																										
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																										
Z	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
Z	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
Z	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
Z	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
Z	2016	Malibu	Body	Electric A/C Compressor Control Module																																																									
Z	2016	Malibu	Body	Seat Memory Control Module - Driver																																																										
Z	2016	Malibu	Body	Keyless Entry Control Module																																																										
Z	2016	Malibu	Body	Right Side Object Detection Control Module																																																										
Z	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
Z	2016	Malibu	Body	Parking Assist Control Module																																																										
Z	2016	Malibu	Body	Frontview Camera Module																																																										
Z	2016	Malibu	Body	Frontview Camera Module																																																										
Z	2016	Malibu	Body	Steering Column Lock Control Module																																																										
Z	2016	Malibu	Body	Long Range Radar Sensor Module		V																																																								
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
1	2013	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2013	Malibu	Chassis	Parking Brake Control Module																																																										
1	2013	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2013	Malibu	Chassis	Power Steering Control Module																																																										
1	2013	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2013	Malibu	Chassis	Suspension Control Module																																																										
1	2013	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2013	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																									
1	2013	Malibu	Body	Passenger Presence Module																																																										
1	2013	Malibu	Body	Instrument Cluster																																																										
1	2013	Malibu	Body	Headlamp Control Module																																																										
1	2013	Malibu	Body	Radio																																																										
1	2013	Malibu	Body	Digital Radio Receiver Control Module																																																										
1	2013	Malibu	Body	Multimedia Player Interface Module																																																										
1	2013	Malibu	Body	Mobile Telephone Control Module																																																										
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2013	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
1	2013	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
1	2013	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2013	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2013	Malibu	Body	Keyless Entry Control Module																																																										
1	2013	Malibu	Body	Parking Assist Control Module																																																										
1	2013	Malibu	Body	Vehicle Direction Camera Control Module																																																										
1	2013	Malibu	Body	Steering Column Lock Control Module																																																										
1	2013	Malibu	Body	Battery Energy Control Module																																																										
1	2014	Impala	Powertrain	(R) 2.4L LUK Engine Control Module																																																										
1	2014	Impala	Powertrain	(R) 2.4L LUK Transmission Control Module																																																										
1	2014	Impala	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																										
1	2014	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																										
1	2014	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																										
1	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																										
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																										
1	2014	Impala	Chassis	Electronic Brake Control Module																																																										
1	2014	Impala	Chassis	Distance Sensing Cruise Control Module																																																										
1	2014	Impala	Chassis	Parking Brake Control Module																																																										
1	2014	Impala	Chassis	Power Steering Control Module																																																										
1	2014	Impala	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2014	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2014	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Impala	Body	Passenger Presence Module																																																										
1	2014	Impala	Body	Instrument Cluster																																																										
1	2014	Impala	Body	Radio Control																																																										
1	2014	Impala	Body	HVAC Control																																																										
1	2014	Impala	Body	Radio																																																										
1	2014	Impala	Body	Amplifier																																																										
1	2014	Impala	Body	Human Machine Interface Control Module																																																										
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Impala	Body	HVAC Control Module																																																										
1	2014	Impala	Body	Keyless Entry Control Module																																																										
1	2014	Impala	Body	Right Side Object Detection Control Module																																																										
1	2014	Impala	Body	Left Side Object Detection Control Module																																																										
1	2014	Impala	Body	Parking Assist Control Module																																																										
1	2014	Impala	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2014	Impala	Body	Steering Column Lock Control Module																																																									
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
1	2014	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
1	2014	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																										
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
1	2014	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																										
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
1	2014	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																										
1	2014	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																										
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
1	2014	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																										
1	2014	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2014	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2014	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																										
1	2014	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																										
1	2014	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																										
1	2014	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																										
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																										
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																										
1	2014	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																										
1	2014	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																										
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
1	2014	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
1	2014	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2014	Malibu	Chassis	Parking Brake Control Module																																																										
1	2014	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2014	Malibu	Chassis	Power Steering Control Module																																																										
1	2014	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2014	Malibu	Chassis	Suspension Control Module																																																										
1	2014	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2014	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																										
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																										
1	2014	Malibu	Body	Passenger Presence Module																																																										
1	2014	Malibu	Body	Instrument Cluster																																																										
1	2014	Malibu	Body	Headlamp Control Module																																																										
1	2014	Malibu	Body	Radio																																																									
1	2014	Malibu	Body	Digital Radio Receiver Control Module																																																										
1	2014	Malibu	Body	Multimedia Player Interface Module																																																										
1	2014	Malibu	Body	Mobile Telephone Control Module																																																										
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
1	2014	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2014	Malibu	Body	HVAC Control Module Manual Single (C67)																																																									
1	2014	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																									
1	2014	Malibu	Body	Rear Seat Heating Control Module																																																									
1	2014	Malibu	Body	Keyless Entry Control Module																																																									
1	2014	Malibu	Body	Left Side Object Detection Control Module																																																									
1	2014	Malibu	Body	Parking Assist Control Module																																																									
1	2014	Malibu	Body	Frontview Camera Module																																																									
1	2014	Malibu	Body	Steering Column Lock Control Module																																																									
1	2015	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																									
1	2015	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																									
1	2015	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																									
1	2015	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																									
1	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
1	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																									
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																									
1	2015	Impala	Chassis	Electronic Brake Control Module																																																									
1	2015	Impala	Chassis	Distance Sensing Cruise Control Module																																																									
1	2015	Impala	Chassis	Parking Brake Control Module																																																									
1	2015	Impala	Chassis	Power Steering Control Module																																																									
1	2015	Impala	Chassis	Power Steering Control Module																																																									
1	2015	Impala	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2015	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
1	2015	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
1	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2015	Impala	Body	Passenger Presence Module																																																									
1	2015	Impala	Body	Instrument Cluster																																																									
1	2015	Impala	Body	Radio Control																																																									
1	2015	Impala	Body	HVAC Control																																																									
1	2015	Impala	Body	Radio																																																									
1	2015	Impala	Body	Amplifier																																																									
1	2015	Impala	Body	Human Machine Interface Control Module																																																									
1	2015	Impala	Body	Telematics Communication Interface Control Module																																																									
1	2015	Impala	Body	HVAC Control Module																																																									
1	2015	Impala	Body	Keyless Entry Control Module																																																									
1	2015	Impala	Body	Right Side Object Detection Control Module																																																									
1	2015	Impala	Body	Left Side Object Detection Control Module																																																									
1	2015	Impala	Body	Parking Assist Control Module																																																									
1	2015	Impala	Body	Frontview Camera Module																																																									
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																									
1	2015	Malibu	Powertrain	2.0L LBN Chassis Control Module																																																									
1	2015	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																									
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	2.0L LBS Chassis Control Module																																																									
1	2015	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																									
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2015	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																								
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																									
1	2015	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																									
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	2.4L LE9 Chassis Control Module																																																									
1	2015	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																									
1	2015	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																									
1	2015	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																									
1	2015	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																									
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																									
1	2015	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																									
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	3.0L LFW Chassis Control Module																																																									
1	2015	Malibu	Powertrain	3.0L LFW Transmission Control Module																																																									
1	2015	Malibu	Powertrain	Rear Differential Clutch Control Module																																																									
1	2015	Malibu	Chassis	Electronic Brake Control Module																																																									
1	2015	Malibu	Chassis	Parking Brake Control Module																																																									
1	2015	Malibu	Chassis	Power Steering Control Module																																																									
1	2015	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2015	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
1	2015	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
1	2015	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2015	Malibu	Body	Passenger Presence Module																																																									
1	2015	Malibu	Body	Instrument Cluster																																																									
1	2015	Malibu	Body	Headlamp Control Module																																																									
1	2015	Malibu	Body	Radio																																																								
1	2015	Malibu	Body	Digital Radio Receiver Control Module																																																									
1	2015	Malibu	Body	Multimedia Player Interface Module																																																									
1	2015	Malibu	Body	Mobile Telephone Control Module																																																									
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																									
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2015	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																									
1	2015	Malibu	Body	HVAC Control Module Auto Single (C68)																																																									
1	2015	Malibu	Body	HVAC Control Module Manual Single (C67)																																																									
1	2015	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																									
1	2015	Malibu	Body	Front Seat Heating Control Module																																																									
1	2015	Malibu	Body	Rear Seat Heating Control Module																																																									
1	2015	Malibu	Body	Keyless Entry Control Module																																																									
1	2015	Malibu	Body	Left Side Object Detection Control Module																																																									
1	2015	Malibu	Body	Parking Assist Control Module																																																									
1	2015	Malibu	Body	Frontview Camera Module																																																									
1	2015	Malibu	Body	Steering Column Lock Control Module																																																									
1	2015	Malibu (LSG)	Powertrain	1.6L LLU Engine Control Module																																																									
1	2015	Malibu (LSG)	Powertrain	Transmission Control Module																																																									
1	2015	Malibu (LSG)	Powertrain	Rear Differential Clutch Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2015	Malibu (LSG)	Chassis	Electronic Brake Control Module																																																									
1	2015	Malibu (LSG)	Chassis	Parking Brake Control Module																																																										
1	2015	Malibu (LSG)	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Malibu (LSG)	Chassis	Suspension Control Module																																																										
1	2015	Malibu (LSG)	Body	Body Control Module																																																										
1	2015	Malibu (LSG)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Malibu (LSG)	Body	Instrument Cluster																																																										
1	2015	Malibu (LSG)	Body	Headlamp Control Module																																																										
1	2015	Malibu (LSG)	Body	Radio																																																										
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Malibu (LSG)	Body	HVAC Control Module																																																										
1	2015	Malibu (LSG)	Body	Front Seat Heating Control Module																																																										
1	2015	Malibu (LSG)	Body	Keyless Entry Control Module																																																										
1	2015	Malibu (LSG)	Body	Left Side Object Detection Control Module																																																										
1	2015	Malibu (LSG)	Body	Parking Assist Control Module																																																										
1	2015	Malibu (LSG)	Body	Frontview Camera Module																																																										
1	2015	Malibu (LSG)	Body	Steering Column Lock Control Module																																																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2016	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																										
1	2016	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																										
1	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2016	Impala	Powertrain	Chassis Control Module																																																										
1	2016	Impala	Chassis	Electronic Brake Control Module																																																										
1	2016	Impala	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Impala	Chassis	Parking Brake Control Module																																																										
1	2016	Impala	Chassis	Power Steering Control Module																																																										
1	2016	Impala	Chassis	Power Steering Control Module																																																										
1	2016	Impala	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2016	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Impala	Body	Passenger Presence Module																																																										
1	2016	Impala	Body	Instrument Cluster																																																										
1	2016	Impala	Body	Radio Control																																																										
1	2016	Impala	Body	HVAC Control																																																										
1	2016	Impala	Body	Radio																																																										
1	2016	Impala	Body	Amplifier																																																										
1	2016	Impala	Body	Human Machine Interface Control Module																																																										
1	2016	Impala	Body	Navigation Control Module																																																										
1	2016	Impala	Body	Telematics Communication Interface Control Module																																																										
1	2016	Impala	Body	HVAC Control Module																																																										
1	2016	Impala	Body	Seat Memory Control Module - Driver																																																										
1	2016	Impala	Body	Keyless Entry Control Module																																																										
1	2016	Impala	Body	Right Side Object Detection Control Module																																																										
1	2016	Impala	Body	Left Side Object Detection Control Module																																																										
1	2016	Impala	Body	Parking Assist Control Module																																																										
1	2016	Impala	Body	Frontview Camera Module																																																										
1	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																											
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
1	2016	Malibu	Powertrain	Fuel Injector Control Module																																																											
1	2016	Malibu	Powertrain	Chassis Control Module																																																											
1	2016	Malibu	Chassis	Electronic Brake Control Module																																																											
1	2016	Malibu	Chassis	Parking Brake Control Module																																																											
1	2016	Malibu	Chassis	Power Steering Control Module																																																											
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2016	Malibu	Body	Passenger Presence Module																																																											
1	2016	Malibu	Body	Instrument Cluster																																																											
1	2016	Malibu	Body	Headlamp Control Module																																																											
1	2016	Malibu	Body	Radio																																																										
1	2016	Malibu	Body	Digital Radio Receiver Control Module																																																										
1	2016	Malibu	Body	Multimedia Player Interface Module																																																										
1	2016	Malibu	Body	Mobile Telephone Control Module																																																										
1	2016	Malibu	Body	Telematics Communication Interface Control Module																																																										
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
1	2016	Malibu	Body	Seat Memory Control Module																																																										
1	2016	Malibu	Body	Front Seat Heating Control Module																																																										
1	2016	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2016	Malibu	Body	Keyless Entry Control Module																																																										
1	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2016	Malibu	Body	Parking Assist Control Module																																																										
1	2016	Malibu	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2005	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module			V		V																																																						
A	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module			V		V																																																						
A	2005	ALL	Powertrain	Transmission Control Module																																																												
A	2005	ALL	Chassis	Power Steering Control Module																																																												
A	2005	ALL	Chassis	Anti-lock Brake System													V																																														
A	2005	ALL	Body	Body Control Module			V																																				V																				
A	2005	ALL	Body	Digital Radio Receiver																																																											
A	2005	ALL	Body	Instrument Panel																																																											
A	2005	ALL	Body	Radio																																																											
A	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
A	2006	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module			V		V																																																						
A	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module			V		V																																																						
A	2006	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module					V																																																						
A	2006	ALL	Powertrain	Transmission Control Module																																																											
A	2006	ALL	Chassis	Power Steering Control Module																																																											
A	2006	ALL	Chassis	Anti-lock Brake System													V																																													
A	2006	ALL	Body	Body Control Module			V																																				V																				
A	2006	ALL	Body	Digital Radio Receiver																																																											
A	2006	ALL	Body	Instrument Panel																																																											
A	2006	ALL	Body	Radio																																																											
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
A	2006	ALL	Body	Theft Deterrent Module		V																																																									
A	2007	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module			V		V																																																						
A	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module					V																																																		V				
A	2007	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module					V																																																						
A	2007	ALL	Powertrain	Transmission Control Module																																																												
A	2007	ALL	Chassis	Power Steering Control Module																																																												
A	2007	ALL	Chassis	Electronic Brake Control Module											V	V	V																																														
A	2007	ALL	Body	Body Control Module			V																																V				V																				
A	2007	ALL	Body	Digital Radio Receiver																																																											
A	2007	ALL	Body	Instrument Panel Cluster																																																											
A	2007	ALL	Body	Passenger Presence System																																																											
A	2007	ALL	Body	Personal Audio Link Module																																																											
A	2007	ALL	Body	Radio								V																																																		
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
A	2007	ALL	Body	Theft Deterrent Module		V																																																									
A	2008	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module					V																																																	V				
A	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module					V																																																	V				
A	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module					V																																																						
A	2008	ALL	Powertrain	Transmission Control Module																																																											
A	2008	ALL	Chassis	Power Steering Control Module																																																											
A	2008	ALL	Chassis	Electronic Brake Control Module with VSES											V	V	V																																														
A	2008	ALL	Chassis	Electronic Brake Control Module without VSES											V	V	V																																														
A	2008	ALL	Body	Body Control Module			V																																V				V																				
A	2008	ALL	Body	Digital Radio Receiver																																																											
A	2008	ALL	Body	Instrument Panel Cluster																																																											
A	2008	ALL	Body	Passenger Presence System																																																											
A	2008	ALL	Body	Personal Audio Link Module																																																											
A	2008	ALL	Body	Radio								V																																																		
A	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
A	2008	ALL	Body	Theft Deterrent Module		V																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2009	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module					V																																																	V	
A	2009	ALL	Powertrain	(H)2.2L L4 LAP Engine Control Module					V																																															V		V
A	2009	ALL	Powertrain	Transmission Control Module																																																						
A	2009	ALL	Chassis	Power Steering Control Module																																																						
A	2009	ALL	Chassis	Electronic Brake Control Module with VSES											V	V	V																																									
A	2009	ALL	Chassis	Electronic Brake Control Module without VSES											V	V	V																																									
A	2009	ALL	Body	Body Control Module			V																																V				V																
A	2009	ALL	Body	Digital Radio Receiver																																																						
A	2009	ALL	Body	Instrument Panel Cluster																																																						
A	2009	ALL	Body	Passenger Presence System																																																						
A	2009	ALL	Body	Personal Audio Link Module																																																						
A	2009	ALL	Body	Radio								V																																															
A	2009	ALL	Body	Supplemental Inflatable Restraint																																																						
A	2009	ALL	Body	Theft Deterrent Module		V																																																				
A	2010	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module					V																																																V		
A	2010	ALL	Powertrain	(5)2.2L L4 LAP Engine Control Module					V																																															V		V
A	2010	ALL	Powertrain	Transmission Control Module																																																						
A	2010	ALL	Chassis	Power Steering Control Module																																																						
A	2010	ALL	Chassis	Electronic Brake Control Module with VSES											V	V	V																																									
A	2010	ALL	Chassis	Electronic Brake Control Module without VSES											V	V	V																																									
A	2010	ALL	Body	Body Control Module			V																																V				V																
A	2010	ALL	Body	Digital Radio Receiver																																																						
A	2010	ALL	Body	Driver Information Center																																																						
A	2010	ALL	Body	Instrument Panel Cluster																																																						
A	2010	ALL	Body	Passenger Presence System																																																						
A	2010	ALL	Body	Personal Audio Link Module																																																						
A	2010	ALL	Body	Radio								V																																															
A	2010	ALL	Body	Supplemental Inflatable Restraint																																																						
A	2010	ALL	Body	Theft Deterrent Module		V																																																				
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																						
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																						
A	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																						
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																						
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																						
A	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																						
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																						
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																						
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																						
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																						
A	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																						
A	2012	Cobalt	Chassis	Electronic Brake Control Module																																																						
A	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																						
A	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																						
A	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																						
A	2012	Cobalt	Body	Body Control Module																																																						
A	2012	Cobalt	Body	Passenger Presence Module																																																						
A	2012	Cobalt	Body	Instrument Cluster																																																						
A	2012	Cobalt	Body	Radio																																																						
A	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																						
A	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																						
A	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2012	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2012	Cobalt	Body	Parking Assist Control Module																																																										
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2013	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	Cobalt	Body	Body Control Module																																																										
A	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	Cobalt	Body	Instrument Cluster																																																										
A	2013	Cobalt	Body	Radio																																																										
A	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																										
A	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
A	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2013	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2013	Cobalt	Body	Parking Assist Control Module																																																										
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2014	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	Cobalt	Body	Body Control Module																																																										
A	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	Cobalt	Body	Instrument Cluster																																																										
A	2014	Cobalt	Body	Radio																																																										
A	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2014	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2014	Cobalt	Body	Parking Assist Control Module																																																										
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2015	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	Cobalt	Body	Body Control Module																																																										
A	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	Cobalt	Body	Instrument Cluster																																																										
A	2015	Cobalt	Body	Radio																																																										
A	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																										
A	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
A	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2015	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2015	Cobalt	Body	Parking Assist Control Module																																																										
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2016	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	Cobalt	Body	Body Control Module																																																										
A	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	Cobalt	Body	Instrument Cluster																																																										
A	2016	Cobalt	Body	Radio Other																																																										
A	2016	Cobalt	Body	Radio (IOB)																																																										
A	2016	Cobalt	Body	Radio (UF7)																																																										
A	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2016	Cobalt	Body	Front Seat Heating Control Module																																																										
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																										
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																										
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2010	Beat	Powertrain	Transmission Control Module																																																										
B	2010	Beat	Chassis	Electronic Brake Control Module																																																										
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2010	Beat	Chassis	Power Steering Control Module																																																										
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2010	Beat	Body	Instrument Cluster																																																										
B	2010	Beat	Body	Keyless Entry Control Module																																																										
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																										
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																										
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2011	Beat	Powertrain	Transmission Control Module																																																										
B	2011	Beat	Chassis	Electronic Brake Control Module																																																										
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2011	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2011	Beat	Body	Instrument Cluster																																																										
B	2011	Beat	Body	Keyless Entry Control Module																																																										
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2012	Beat	Powertrain	Transmission Control Module																																																										
B	2012	Beat	Chassis	Electronic Brake Control Module																																																										
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2012	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2012	Beat	Body	Instrument Cluster																																																										
B	2012	Beat	Body	Keyless Entry Control Module																																																										
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2013	Beat	Powertrain	Transmission Control Module																																																										
B	2013	Beat	Chassis	Electronic Brake Control Module																																																										
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2013	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2013	Beat	Body	Instrument Cluster																																																										
B	2013	Beat	Body	Keyless Entry Control Module																																																										
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2014	Beat	Powertrain	Transmission Control Module																																																										
B	2014	Beat	Powertrain	Fuel Injector Control Module																																																										
B	2014	Beat	Chassis	Electronic Brake Control Module																																																										
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
B	2014	Beat	Chassis	Power Steering Control Module																																																											
B	2014	Beat	Chassis	Steering Wheel Angle Sensor Module																																																											
B	2014	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
B	2014	Beat	Body	Instrument Cluster																																																											
B	2014	Beat	Body	Telematics Communication Interface Control Module																																																											
B	2015	Beat	Powertrain	1.0L LEB Engine Control Module																																																											
B	2015	Beat	Powertrain	1.19L LC5 Engine Control Module																																																											
B	2015	Beat	Powertrain	Transmission Control Module																																																											
B	2015	Beat	Powertrain	Fuel Injector Control Module																																																											
B	2015	Beat	Chassis	Electronic Brake Control Module																																																											
B	2015	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																											
B	2015	Beat	Chassis	Power Steering Control Module																																																											
B	2015	Beat	Chassis	Steering Wheel Angle Sensor Module																																																											
B	2015	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
B	2015	Beat	Body	Instrument Cluster																																																											
B	2015	Beat	Body	Radio																																																											
B	2015	Beat	Body	Telematics Communication Interface Control Module																																																											
B	2015	Beat	Body	Keyless Entry Control Module																																																											
B	2016	Beat	Powertrain	1.0L LEB Engine Control Module																																																											
B	2016	Beat	Powertrain	1.19L LC5 Engine Control Module																																																											
B	2016	Beat	Powertrain	Transmission Control Module																																																											
B	2016	Beat	Chassis	Electronic Brake Control Module																																																											
B	2016	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																											
B	2016	Beat	Chassis	Power Steering Control Module																																																											
B	2016	Beat	Chassis	Steering Wheel Angle Sensor Module																																																											
B	2016	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
B	2016	Beat	Body	Instrument Cluster																																																											
B	2016	Beat	Body	Radio																																																											
B	2016	Beat	Body	Telematics Communication Interface Control Module																																																											
B	2016	Beat	Body	HVAC Control Module																																																											
B	2016	Beat	Body	Keyless Entry Control Module																																																											
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																											
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																											
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																											
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																											
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																											
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																											
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																											
B	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																											
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																											
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																											
B	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																											
B	2016	Cruze	Chassis	Electronic Brake Control Module																																																											
B	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																											
B	2016	Cruze	Chassis	Power Steering Control Module																																																											
B	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
B	2016	Cruze	Body	Body Control Module																																																											
B	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
B	2016	Cruze	Body	Passenger Presence Module																																																											
B	2016	Cruze	Body	Instrument Cluster																																																											
B	2016	Cruze	Body	Radio Controls																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
B	2016	Cruze	Body	HVAC Controls																																																										
B	2016	Cruze	Body	Trailer Interface Control Module																																																										
B	2016	Cruze	Body	Radio Base (IO3 IO7)																																																										
B	2016	Cruze	Body	Radio (IOA)																																																										
B	2016	Cruze	Body	Radio (IOB)																																																										
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																										
B	2016	Cruze	Body	Amplifier																																																										
B	2016	Cruze	Body	Multimedia Player Interface Module																																																										
B	2016	Cruze	Body	Human Machine Interface Control Module																																																										
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																										
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																										
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																										
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																										
B	2016	Cruze	Body	Keyless Entry Control Module																																																										
B	2016	Cruze	Body	Right Side Object Detection Control Module																																																										
B	2016	Cruze	Body	Left Side Object Detection Control Module																																																										
B	2016	Cruze	Body	Parking Assist Control Module																																																										
B	2016	Cruze	Body	Frontview Camera Module																																																										
B	2016	Cruze	Body	Steering Column Lock Control Module																																																										
B	2016	Cruze	Body	Long Range Radar Sensor Module																																																										
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2010	Spark	Powertrain	Transmission Control Module																																																										
C	2010	Spark	Chassis	Electronic Brake Control Module																																																										
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2010	Spark	Chassis	Electric Power Steering Control Module																																																										
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2010	Spark	Body	Passenger Presence Module																																																										
C	2010	Spark	Body	Instrument Cluster																																																										
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
C	2011	Spark	Powertrain	Transmission Control Module																																																										
C	2011	Spark	Chassis	Electronic Brake Control Module																																																										
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2011	Spark	Chassis	Electric Power Steering Control Module																																																										
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2011	Spark	Body	Passenger Presence Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2011	Spark	Body	Instrument Cluster																																																												
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																												
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																												
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																												
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																												
C	2012	Spark	Powertrain	Transmission Control Module																																																												
C	2012	Spark	Chassis	Electronic Brake Control Module																																																												
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2012	Spark	Chassis	Electric Power Steering Control Module																																																												
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2012	Spark	Body	Passenger Presence Module																																																												
C	2012	Spark	Body	Instrument Cluster																																																												
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																												
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																												
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																												
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																												
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
C	2013	Spark	Powertrain	Fuel Injector Control Module																																																												
C	2013	Spark	Chassis	Electronic Brake Control Module																																																												
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2013	Spark	Chassis	Power Steering Control Module																																																												
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2013	Spark	Body	Body Control Module																																																												
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2013	Spark	Body	Passenger Presence Module																																																												
C	2013	Spark	Body	Instrument Cluster																																																												
C	2013	Spark	Body	Radio																																																												
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																												
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																												
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
C	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
C	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
C	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2014	Spark	Chassis	Electronic Brake Control Module																																																										
C	2014	Spark	Chassis	Electronic Brake Control Module																																																										
C	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2014	Spark	Chassis	Power Steering Control Module																																																										
C	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Spark	Body	Body Control Module																																																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark	Body	Passenger Presence Module																																																										
C	2014	Spark	Body	Instrument Cluster																																																										
C	2014	Spark	Body	Radio																																																										
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Spark	Body	Keyless Entry Control Module																																																										
C	2014	Spark EV	Powertrain	Engine Control Module																																																										
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
C	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
C	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
C	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
C	2014	Spark EV	Chassis	Power Steering Control Module																																																										
C	2014	Spark EV	Body	Body Control Module																																																										
C	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark EV	Body	Passenger Presence Module																																																										
C	2014	Spark EV	Body	Instrument Cluster																																																										
C	2014	Spark EV	Body	Radio																																																										
C	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Spark EV	Body	HVAC Control Module																																																										
C	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2014	Spark EV	Body	Coolant Heater Control Module																																																										
C	2014	Spark EV	Body	Keyless Entry Control Module																																																										
C	2014	Spark EV	Body	Battery Charger Control Module																																																										
C	2014	Spark EV	Body	DC Charging Control Module																																																										
C	2014	Spark EV	Body	Battery Energy Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
C	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Spark	Chassis	Power Steering Control Module																																																										
C	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Spark	Body	Body Control Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Passenger Presence Module																																																										
C	2015	Spark	Body	Instrument Cluster																																																										
C	2015	Spark	Body	Instrument Cluster																																																										
C	2015	Spark	Body	Tire Pressure Indicator Module																																																										
C	2015	Spark	Body	Radio																																																										
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Spark	Body	Keyless Entry Control Module																																																										
C	2015	Spark EV	Powertrain	Engine Control Module																																																										
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
C	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
C	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
C	2015	Spark EV	Chassis	Power Steering Control Module																																																										
C	2015	Spark EV	Body	Body Control Module																																																										
C	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark EV	Body	Passenger Presence Module																																																										
C	2015	Spark EV	Body	Instrument Cluster																																																										
C	2015	Spark EV	Body	Radio																																																										
C	2015	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																											
C	2015	Spark EV	Body	Coolant Heater Control Module																																																											
C	2015	Spark EV	Body	Keyless Entry Control Module																																																											
C	2015	Spark EV	Body	Battery Charger Control Module																																																											
C	2015	Spark EV	Body	DC Charging Control Module																																																											
C	2015	Spark EV	Body	Battery Energy Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	Fuel Injector Control Module																																																											
C	2016	Spark	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2016	Spark	Chassis	Power Steering Control Module																																																											
C	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Spark	Body	Body Control Module																																																											
C	2016	Spark	Body	Body Control Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Instrument Cluster																																																											
C	2016	Spark	Body	Instrument Cluster																																																											
C	2016	Spark	Body	Radio																																																											
C	2016	Spark	Body	Telematics Communication Interface Control Module																																																											
C	2016	Spark	Body	Keyless Entry Control Module																																																											
C	2016	Spark EV	Powertrain	Engine Control Module																																																											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
C	2016	Spark EV	Powertrain	Drive Motor Control Module																																																											
C	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
C	2016	Spark EV	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark EV	Chassis	Parking Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2016	Spark EV	Chassis	Power Steering Control Module																																																										
C	2016	Spark EV	Body	Body Control Module																																																										
C	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Spark EV	Body	Passenger Presence Module																																																										
C	2016	Spark EV	Body	Instrument Cluster																																																										
C	2016	Spark EV	Body	Radio																																																										
C	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
C	2016	Spark EV	Body	HVAC Control Module																																																										
C	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2016	Spark EV	Body	Coolant Heater Control Module																																																										
C	2016	Spark EV	Body	Keyless Entry Control Module																																																										
C	2016	Spark EV	Body	Frontview Camera Module																																																										
C	2016	Spark EV	Body	Battery Charger Control Module																																																										
C	2016	Spark EV	Body	DC Charging Control Module																																																										
C	2016	Spark EV	Body	Battery Energy Control Module																																																										
D	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2010	Spark	Powertrain	Transmission Control Module																																																										
D	2010	Spark	Chassis	Electronic Brake Control Module																																																										
D	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2010	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2010	Spark	Body	Passenger Presence Module																																																										
D	2010	Spark	Body	Instrument Cluster																																																										
D	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										
D	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
D	2011	Spark	Powertrain	Transmission Control Module																																																										
D	2011	Spark	Chassis	Electronic Brake Control Module																																																										
D	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2011	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2011	Spark	Body	Passenger Presence Module																																																										
D	2011	Spark	Body	Instrument Cluster																																																										
D	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																											
D	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																											
D	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																											
D	2012	Spark	Powertrain	Transmission Control Module																																																											
D	2012	Spark	Chassis	Electronic Brake Control Module																																																											
D	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2012	Spark	Chassis	Electric Power Steering Control Module																																																											
D	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2012	Spark	Body	Passenger Presence Module																																																											
D	2012	Spark	Body	Instrument Cluster																																																											
D	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
D	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
D	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																											
D	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																											
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
D	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
D	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																											
D	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																											
D	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
D	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2013	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2013	Spark	Chassis	Electronic Brake Control Module																																																											
D	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2013	Spark	Chassis	Power Steering Control Module																																																											
D	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2013	Spark	Body	Body Control Module																																																											
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2013	Spark	Body	Passenger Presence Module																																																											
D	2013	Spark	Body	Instrument Cluster																																																											
D	2013	Spark	Body	Radio																																																											
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
D	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
D	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																											
D	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
D	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2014	Spark	Chassis	Electronic Brake Control Module																																																										
D	2014	Spark	Chassis	Electronic Brake Control Module																																																										
D	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2014	Spark	Chassis	Power Steering Control Module																																																										
D	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2014	Spark	Body	Body Control Module																																																										
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	Spark	Body	Passenger Presence Module																																																										
D	2014	Spark	Body	Instrument Cluster																																																										
D	2014	Spark	Body	Radio																																																										
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2014	Spark	Body	Keyless Entry Control Module																																																										
D	2014	Spark EV	Powertrain	Engine Control Module																																																										
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
D	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
D	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
D	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
D	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
D	2014	Spark EV	Chassis	Power Steering Control Module																																																										
D	2014	Spark EV	Body	Body Control Module																																																										
D	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
D	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	Spark EV	Body	Passenger Presence Module																																																										
D	2014	Spark EV	Body	Instrument Cluster																																																										
D	2014	Spark EV	Body	Radio																																																										
D	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2014	Spark EV	Body	HVAC Control Module																																																										
D	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																										
D	2014	Spark EV	Body	Coolant Heater Control Module																																																										
D	2014	Spark EV	Body	Keyless Entry Control Module																																																										
D	2014	Spark EV	Body	Battery Charger Control Module																																																										
D	2014	Spark EV	Body	DC Charging Control Module																																																										
D	2014	Spark EV	Body	Battery Energy Control Module																																																										
D	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
D	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
D	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2015	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2015	Spark	Chassis	Electronic Brake Control Module																																																											
D	2015	Spark	Chassis	Electronic Brake Control Module																																																											
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2015	Spark	Chassis	Power Steering Control Module																																																											
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2015	Spark	Body	Body Control Module																																																											
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark	Body	Passenger Presence Module																																																											
D	2015	Spark	Body	Instrument Cluster																																																											
D	2015	Spark	Body	Instrument Cluster																																																											
D	2015	Spark	Body	Tire Pressure Indicator Module																																																											
D	2015	Spark	Body	Radio																																																											
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2015	Spark	Body	Keyless Entry Control Module																																																											
D	2015	Spark EV	Powertrain	Engine Control Module																																																											
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
D	2015	Spark EV	Powertrain	Drive Motor Control Module																																																											
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
D	2015	Spark EV	Chassis	Electronic Brake Control Module																																																											
D	2015	Spark EV	Chassis	Parking Brake Control Module																																																											
D	2015	Spark EV	Chassis	Power Steering Control Module																																																											
D	2015	Spark EV	Body	Body Control Module																																																											
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark EV	Body	Passenger Presence Module																																																											
D	2015	Spark EV	Body	Instrument Cluster																																																											
D	2015	Spark EV	Body	Radio																																																											
D	2015	Spark EV	Body	HVAC Control Module																																																											
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																											
D	2015	Spark EV	Body	Coolant Heater Control Module																																																											
D	2015	Spark EV	Body	Keyless Entry Control Module																																																											
D	2015	Spark EV	Body	Battery Charger Control Module																																																											
D	2015	Spark EV	Body	DC Charging Control Module																																																											
D	2015	Spark EV	Body	Battery Energy Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
D	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2016	Spark	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2016	Spark	Chassis	Power Steering Control Module																																																										
D	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2016	Spark	Body	Body Control Module																																																										
D	2016	Spark	Body	Body Control Module																																																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark	Body	Instrument Cluster																																																										
D	2016	Spark	Body	Instrument Cluster																																																										
D	2016	Spark	Body	Radio																																																										
D	2016	Spark	Body	Telematics Communication Interface Control Module																																																										
D	2016	Spark	Body	Keyless Entry Control Module																																																										
D	2016	Spark EV	Powertrain	Engine Control Module																																																										
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
D	2016	Spark EV	Powertrain	Drive Motor Control Module																																																										
D	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
D	2016	Spark EV	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark EV	Chassis	Parking Brake Control Module																																																										
D	2016	Spark EV	Chassis	Power Steering Control Module																																																										
D	2016	Spark EV	Body	Body Control Module																																																										
D	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
D	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark EV	Body	Passenger Presence Module																																																										
D	2016	Spark EV	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2016	Spark EV	Body	Radio																																																										
D	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
D	2016	Spark EV	Body	HVAC Control Module																																																										
D	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
D	2016	Spark EV	Body	Coolant Heater Control Module																																																										
D	2016	Spark EV	Body	Keyless Entry Control Module																																																										
D	2016	Spark EV	Body	Frontview Camera Module																																																										
D	2016	Spark EV	Body	Battery Charger Control Module																																																										
D	2016	Spark EV	Body	DC Charging Control Module																																																										
D	2016	Spark EV	Body	Battery Energy Control Module																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Automatic Transmission																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Manual Transmission																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Transmission Control Module																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2010	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2010	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2010	Camaro	Chassis	Power Steering Control Module																																																										
F	2010	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2010	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2010	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2010	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2010	Camaro	Body	Passenger Presence Module																																																										
F	2010	Camaro	Body	Instrument Cluster																																																										
F	2010	Camaro	Body	Auxiliary Gage Module																																																										
F	2010	Camaro	Body	Radio																																																										
F	2010	Camaro	Body	Multimedia Player Interface Module																																																										
F	2010	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																										
F	2010	Camaro	Body	Mobile Telephone Control Module																																																										
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2010	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																										
F	2010	Camaro	Body	Front Seat Heating Control Module																																																										
F	2010	Camaro	Body	Folding Top Control Module																																																										
F	2010	Camaro	Body	Parking Assist Control Module																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Automatic Transmission																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Manual Transmission																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																											
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2011	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2011	Camaro	Chassis	Power Steering Control Module																																																											
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2011	Camaro	Body	Passenger Presence Module																																																											
F	2011	Camaro	Body	Instrument Cluster																																																											
F	2011	Camaro	Body	Head-Up Display Module																																																											
F	2011	Camaro	Body	Auxiliary Gage Module																																																											
F	2011	Camaro	Body	Headlamp Control Module																																																											
F	2011	Camaro	Body	Radio																																																											
F	2011	Camaro	Body	Multimedia Player Interface Module																																																											
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																											
F	2011	Camaro	Body	Mobile Telephone Control Module																																																											
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																											
F	2011	Camaro	Body	Front Seat Heating Control Module																																																											
F	2011	Camaro	Body	Folding Top Control Module																																																											
F	2011	Camaro	Body	Parking Assist Control Module																																																											
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																											
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																											
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																											
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																											
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module																																																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																											
F	2012	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2012	Camaro	Chassis	Power Steering Control Module																																																											
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2012	Camaro	Chassis	Suspension Control Module																																																											
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2012	Camaro	Body	Passenger Presence Module																																																											
F	2012	Camaro	Body	Instrument Cluster																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
F	2012	Camaro	Body	Head-Up Display Module																																																										
F	2012	Camaro	Body	Auxiliary Gage Module																																																										
F	2012	Camaro	Body	Headlamp Control Module																																																										
F	2012	Camaro	Body	Radio																																																										
F	2012	Camaro	Body	Multimedia Player Interface Module																																																										
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																										
F	2012	Camaro	Body	Mobile Telephone Control Module																																																										
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																										
F	2012	Camaro	Body	Front Seat Heating Control Module																																																										
F	2012	Camaro	Body	Folding Top Control Module																																																										
F	2012	Camaro	Body	Parking Assist Control Module																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																										
F	2013	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2013	Camaro	Chassis	Power Steering Control Module																																																										
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2013	Camaro	Chassis	Suspension Control Module																																																										
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2013	Camaro	Body	Passenger Presence Module																																																										
F	2013	Camaro	Body	Instrument Cluster																																																										
F	2013	Camaro	Body	Head-Up Display Module																																																										
F	2013	Camaro	Body	Auxiliary Gage Module																																																										
F	2013	Camaro	Body	Headlamp Control Module																																																										
F	2013	Camaro	Body	Radio																																																										
F	2013	Camaro	Body	Multimedia Player Interface Module																																																										
F	2013	Camaro	Body	Mobile Telephone Control Module																																																										
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
F	2013	Camaro	Body	HVAC Control Module																																																										
F	2013	Camaro	Body	Front Seat Heating Control Module																																																											
F	2013	Camaro	Body	Folding Top Control Module																																																											
F	2013	Camaro	Body	Parking Assist Control Module																																																											
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																											
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																											
F	2014	Camaro	Powertrain	Transmission Control Module																																																											
F	2014	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2014	Camaro	Chassis	Parking Brake Control Module																																																											
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2014	Camaro	Chassis	Power Steering Control Module																																																											
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2014	Camaro	Chassis	Suspension Control Module																																																											
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2014	Camaro	Body	Passenger Presence Module																																																											
F	2014	Camaro	Body	Instrument Cluster																																																											
F	2014	Camaro	Body	Head-Up Display Module																																																											
F	2014	Camaro	Body	Auxiliary Gage Module																																																											
F	2014	Camaro	Body	Headlamp Control Module																																																											
F	2014	Camaro	Body	Radio																																																											
F	2014	Camaro	Body	Mobile Telephone Control Module																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2014	Camaro	Body	HVAC Control Module																																																											
F	2014	Camaro	Body	Front Seat Heating Control Module																																																											
F	2014	Camaro	Body	Folding Top Control Module																																																											
F	2014	Camaro	Body	Parking Assist Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2014	SS	Powertrain	Chassis Control Module																																																											
F	2014	SS	Chassis	Electronic Brake Control Module																																																											
F	2014	SS	Chassis	Parking Brake Control Module																																																											
F	2014	SS	Chassis	Power Steering Control Module																																																											
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2014	SS	Body	Body Control Module																																																											
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2014	SS	Body	Passenger Presence Module																																																											
F	2014	SS	Body	Instrument Cluster																																																											
F	2014	SS	Body	Head-Up Display Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
F	2014	SS	Body	Radio Control																																																											
F	2014	SS	Body	HVAC Control																																																												
F	2014	SS	Body	Headlamp Control Module																																																												
F	2014	SS	Body	Trailer Interface Control Module																																																												
F	2014	SS	Body	Radio																																																												
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2014	SS	Body	HVAC Control Module																																																												
F	2014	SS	Body	Seat Memory Control Module - Driver																																																												
F	2014	SS	Body	Keyless Entry Control Module																																																												
F	2014	SS	Body	Right Side Object Detection Control Module																																																												
F	2014	SS	Body	Left Side Object Detection Control Module																																																												
F	2014	SS	Body	Parking Assist Control Module																																																												
F	2014	SS	Body	Frontview Camera Module																																																												
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																												
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																												
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																												
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																												
F	2015	Camaro	Powertrain	Transmission Control Module																																																												
F	2015	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2015	Camaro	Chassis	Power Steering Control Module																																																												
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2015	Camaro	Chassis	Suspension Control Module																																																												
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2015	Camaro	Body	Passenger Presence Module																																																												
F	2015	Camaro	Body	Instrument Cluster																																																												
F	2015	Camaro	Body	Head-Up Display Module																																																												
F	2015	Camaro	Body	Auxiliary Gage Module																																																												
F	2015	Camaro	Body	Headlamp Control Module																																																												
F	2015	Camaro	Body	Radio																																																												
F	2015	Camaro	Body	Mobile Telephone Control Module																																																												
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6																																																												
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																												
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2015	Camaro	Body	HVAC Control Module																																																												
F	2015	Camaro	Body	Front Seat Heating Control Module																																																												
F	2015	Camaro	Body	Folding Top Control Module																																																												
F	2015	Camaro	Body	Parking Assist Control Module																																																												
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2015	SS	Powertrain	Fuel Injector Control Module																																																											
F	2015	SS	Powertrain	Chassis Control Module																																																											
F	2015	SS	Chassis	Electronic Brake Control Module																																																											
F	2015	SS	Chassis	Parking Brake Control Module																																																											
F	2015	SS	Chassis	Power Steering Control Module																																																											
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2015	SS	Chassis	Suspension Control Module																																																											
F	2015	SS	Body	Body Control Module																																																											
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2015	SS	Body	Passenger Presence Module																																																											
F	2015	SS	Body	Instrument Cluster																																																											
F	2015	SS	Body	Head-Up Display Module																																																											
F	2015	SS	Body	Radio Control																																																											
F	2015	SS	Body	HVAC Control																																																											
F	2015	SS	Body	Headlamp Control Module																																																											
F	2015	SS	Body	Trailer Interface Control Module																																																											
F	2015	SS	Body	Radio																																																											
F	2015	SS	Body	Telematics Communication Interface Control Module																																																											
F	2015	SS	Body	HVAC Control Module																																																											
F	2015	SS	Body	Seat Memory Control Module - Driver																																																											
F	2015	SS	Body	Keyless Entry Control Module																																																											
F	2015	SS	Body	Right Side Object Detection Control Module																																																											
F	2015	SS	Body	Left Side Object Detection Control Module																																																											
F	2015	SS	Body	Parking Assist Control Module																																																											
F	2015	SS	Body	Frontview Camera Module																																																											
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																											
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																											
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																											
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																											
F	2016	Camaro	Powertrain	Transmission Control Module																																																											
F	2016	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2016	Camaro	Chassis	Parking Brake Control Module																																																											
F	2016	Camaro	Chassis	Power Steering Control Module																																																											
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2016	Camaro	Chassis	Suspension Control Module																																																											
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2016	Camaro	Body	Serial Data Gateway Module																																																											
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2016	Camaro	Body	Passenger Presence Module																																																											
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																											
F	2016	Camaro	Body	Head-Up Display Module																																																											
F	2016	Camaro	Body	Auxiliary Gage Module																																																											
F	2016	Camaro	Body	Radio Controls																																																											
F	2016	Camaro	Body	HVAC Controls																																																											
F	2016	Camaro	Body	Vehicle Performance Data Recorder																																																											
F	2016	Camaro	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
F	2016	Camaro	Body	Amplifier																																																								
F	2016	Camaro	Body	Media Disc Player																																																								
F	2016	Camaro	Body	Human Machine Interface Control Module																																																								
F	2016	Camaro	Body	Navigation Control Module																																																								
F	2016	Camaro	Body	Mobile Telephone Control Module																																																								
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																								
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)																																																								
F	2016	Camaro	Body	Seat Memory Control Module - Driver																																																								
F	2016	Camaro	Body	Folding Top Control Module																																																								
F	2016	Camaro	Body	Keyless Entry Control Module																																																								
F	2016	Camaro	Body	Right Side Object Detection Control Module																																																								
F	2016	Camaro	Body	Left Side Object Detection Control Module																																																								
F	2016	Camaro	Body	Parking Assist Control Module																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2016	SS	Powertrain	Fuel Injector Control Module																																																								
F	2016	SS	Chassis	Electronic Brake Control Module																																																								
F	2016	SS	Chassis	Parking Brake Control Module																																																								
F	2016	SS	Chassis	Power Steering Control Module																																																								
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2016	SS	Chassis	Suspension Control Module																																																								
F	2016	SS	Body	Body Control Module																																																								
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2016	SS	Body	Passenger Presence Module																																																								
F	2016	SS	Body	Instrument Cluster																																																								
F	2016	SS	Body	Head-Up Display Module																																																								
F	2016	SS	Body	Radio Control																																																								
F	2016	SS	Body	HVAC Control																																																								
F	2016	SS	Body	Trailer Interface Control Module																																																								
F	2016	SS	Body	Radio																																																								
F	2016	SS	Body	Telematics Communication Interface Control Module																																																								
F	2016	SS	Body	HVAC Control Module																																																								
F	2016	SS	Body	Seat Memory Control Module - Driver																																																								
F	2016	SS	Body	Keyless Entry Control Module																																																								
F	2016	SS	Body	Right Side Object Detection Control Module																																																								
F	2016	SS	Body	Left Side Object Detection Control Module																																																								
F	2016	SS	Body	Parking Assist Control Module																																																								
F	2016	SS	Body	Frontview Camera Module																																																								
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
G	2016	Malibu	Powertrain	Fuel Injector Control Module																																																								
G	2016	Malibu	Powertrain	Chassis Control Module																																																								
G	2016	Malibu	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2016	Malibu	Chassis	Parking Brake Control Module																																																										
G	2016	Malibu	Chassis	Power Steering Control Module																																																										
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2016	Malibu	Body	Passenger Presence Module																																																										
G	2016	Malibu	Body	Instrument Cluster																																																										
G	2016	Malibu	Body	Headlamp Control Module																																																										
G	2016	Malibu	Body	Radio																																																										
G	2016	Malibu	Body	Digital Radio Receiver Control Module																																																										
G	2016	Malibu	Body	Multimedia Player Interface Module																																																										
G	2016	Malibu	Body	Mobile Telephone Control Module																																																										
G	2016	Malibu	Body	Telematics Communication Interface Control Module																																																										
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
G	2016	Malibu	Body	Seat Memory Control Module																																																										
G	2016	Malibu	Body	Front Seat Heating Control Module																																																										
G	2016	Malibu	Body	Rear Seat Heating Control Module																																																										
G	2016	Malibu	Body	Keyless Entry Control Module																																																										
G	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
G	2016	Malibu	Body	Parking Assist Control Module																																																										
G	2016	Malibu	Body	Frontview Camera Module																																																										
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
H	2010	Sail	Powertrain	Transmission Control Module																																																							V		
H	2010	Sail	Chassis	Electronic Brake Control Module																																																										
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
H	2011	Sail	Powertrain	Transmission Control Module																																																							V		
H	2011	Sail	Chassis	Electronic Brake Control Module																																																										
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	Transmission Control Module																																																						V		
H	2012	Sail	Chassis	Electronic Brake Control Module																																																										
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
H	2013	Sail	Powertrain	Transmission Control Module																																																						V		
H	2013	Sail	Chassis	Electronic Brake Control Module																																																									
H	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	Transmission Control Module																																																					V		
H	2014	Sail	Chassis	Electronic Brake Control Module																																																										
H	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																										
H	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																										
H	2015	Sail	Chassis	Electronic Brake Control Module																																																										
H	2015	Sail	Chassis	Power Steering Control Module																																																										
H	2015	Sail	Body	Body Control Module																																																									
H	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Sail	Body	Radio/HVAC Control																																																										
H	2015	Sail	Body	HVAC Control Module																																																										
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
H	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																										
H	2016	Sail	Chassis	Electronic Brake Control Module																																																										
H	2016	Sail	Chassis	Power Steering Control Module																																																										
H	2016	Sail	Body	Body Control Module																																																									
H	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Sail	Body	Radio/HVAC Control																																																										
H	2016	Sail	Body	Radio																																																									
H	2016	Sail	Body	HVAC Control Module																																																									
J	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V																	V	
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																							V																	V	
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																									
J	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																									
J	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																									
J	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
J	2004	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																									
J	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																									
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes											V	V	V																																												
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control No													V																																												
J	2004	Optra	Body	Remote Function Actuation																																								V																
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module					V																																																				
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel					V																																																				
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel Transmission Control Module																																																										
J	2004	Cavalier	Chassis	Anti-lock Brake System																																																										
J	2004	Cavalier	Body	Body Control Module																																																										
J	2004	Cavalier	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2004	Cavalier	Body	Instrument Panel Cluster																																																										
J	2004	Cavalier	Body	Radio																																																										
J	2004	Cavalier	Body	Supplemental Inflatable Restraint																	V																																									
J	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V																V	
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																						V	
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																							
J	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																							
J	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																						
J	2005	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																						
J	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																						
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes											V	V	V																																										
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control No													V																																										
J	2005	Optra	Body	Remote Function Actuation																																								V															
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module					V																																																		
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																						
J	2005	Cavalier	Chassis	Anti-lock Brake System																																																						
J	2005	Cavalier	Body	Body Control Module																																																						
J	2005	Cavalier	Body	Digital Radio Receiver																																																						
J	2005	Cavalier	Body	Instrument Panel Cluster																																																						
J	2005	Cavalier	Body	Radio																																																						
J	2005	Cavalier	Body	Supplemental Inflatable Restraint																																																						
J	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																					V	
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																					V	
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																						
J	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																						
J	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																						
J	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																						
J	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																						
J	2006	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																						
J	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																						
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes											V	V	V																																										
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No													V																																										
J	2006	ALL	Body	Remote Function Actuation																																								V															
J	2006	ALL	Body	Supplemental Inflatable Restraint																																																						
J	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																					V	
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																					V	
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																						
J	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																						
J	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																						
J	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module			V																																																			
J	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																			
J	2007	ALL	Powertrain	4 Speed Automatic																																																						
J	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																						
J	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																						
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes											V	V	V																																										
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No													V																																										
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes													V																																										
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No													V																																										
J	2007	ALL	Chassis	Tire Pressure Monitor																																																						
J	2007	ALL	Body	Remote Function Actuation																																								V															
J	2007	ALL	Body	Supplemental Inflatable Restraint																																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								V	
J	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																								V	
J	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								V	
J	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
J	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
J	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																					
J	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module			V																																																					
J	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module			V																																																					
J	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																								
J	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes													V																																										
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No													V																																										
J	2008	ALL	Chassis	Tire Pressure Monitor																																																								
J	2008	ALL	Body	Remote Function Actuation																																								V															
J	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
J	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								V	
J	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																								V	
J	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								V	
J	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
J	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
J	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																					
J	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module			V																																																					
J	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																								
J	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes													V																																										
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No													V																																										
J	2009	ALL	Chassis	Tire Pressure Monitor																																																								
J	2009	ALL	Body	Remote Function Actuation																																								V															
J	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																								
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																						V	
J	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																								
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																								
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																						V	
J	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																								
J	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																								
J	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																							V	
J	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																								
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																								
J	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																								
J	2010	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2010	Cruze	Body	Body Control Module																																																								
J	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2010	Cruze	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2010	Cruze	Body	Instrument Cluster																																																										
J	2010	Cruze	Body	Trailer Interface Control Module																																																										
J	2010	Cruze	Body	Radio																																																										
J	2010	Cruze	Body	Multimedia Player Interface Module																																																										
J	2010	Cruze	Body	Mobile Telephone Control Module																																																										
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
J	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
J	2010	Cruze	Body	Keyless Entry Control Module																																																										
J	2010	Cruze	Body	Parking Assist Control Module																																																										
J	2010	Cruze	Body	Steering Column Lock Control Module																																																										
J	2010	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									V	
J	2010	Other	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																									V	
J	2010	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2010	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																							
J	2010	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
J	2010	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2010	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2010	Other	Powertrain	Transmission Control Module 5 Speed																																																										
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control Yes													V																																													
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control No													V																																													
J	2010	Other	Chassis	Tire Pressure Monitor																																																										
J	2010	Other	Body	Remote Function Actuation																																								V																		
J	2010	Other	Body	Supplemental Inflatable Restraint																																																										
J	2010	Other	Body	Supplemental Inflatable Restraint																																																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission					V																																																					
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission					V																																																	V				
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																										
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																						V				
J	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																										
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																						V				
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission					V																																																					
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission					V																																																					
J	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																										
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																						V				
J	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																										
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																						V				
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission					V																																																					
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission					V																																																					
J	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission					V																																																					
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission					V																																																					
J	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																										
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																							V		
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
J	2011	Cruze	Chassis	Electronic Brake Control Module																																																									
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2011	Cruze	Body	Body Control Module																																																									
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2011	Cruze	Body	Passenger Presence Module																																																									
J	2011	Cruze	Body	Instrument Cluster																																																									
J	2011	Cruze	Body	Trailer Interface Control Module																																																									
J	2011	Cruze	Body	Radio																																																									
J	2011	Cruze	Body	Multimedia Player Interface Module																																																									
J	2011	Cruze	Body	Mobile Telephone Control Module																																																									
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
J	2011	Cruze	Body	Keyless Entry Control Module																																																									
J	2011	Cruze	Body	Parking Assist Control Module																																																									
J	2011	Cruze	Body	Steering Column Lock Control Module																																																									
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																							V		
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																						V		
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																									
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																						
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																									
J	2011	Other	Powertrain	Transmission Control Module 5 Speed																																																									
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes													V																																												
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No													V																																												
J	2011	Other	Chassis	Tire Pressure Monitor																																																									
J	2011	Other	Body	Remote Function Actuation																																								V																	
J	2011	Other	Body	Supplemental Inflatable Restraint																																																									
J	2011	Other	Body	Supplemental Inflatable Restraint																																																									
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2012	Aveo	Powertrain	Fuel Pump Control Module																																																													
J	2012	Aveo	Powertrain	Fuel Injector Control Module																																																												
J	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Aveo	Chassis	Electric Power Steering Control Module																																																												
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Aveo	Body	Body Control Module Hatchback																																																												
J	2012	Aveo	Body	Body Control Module Sedan																																																												
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2012	Aveo	Body	Passenger Presence Module																																																												
J	2012	Aveo	Body	Instrument Cluster																																																												
J	2012	Aveo	Body	Radio																																																											
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																												
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
J	2012	Aveo	Body	Front Seat Heating Control Module																																																												
J	2012	Aveo	Body	Parking Assist Control Module																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																												
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2012	Cobalt	Chassis	Electronic Brake Control Module																																																												
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																												
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Cobalt	Body	Body Control Module																																																												
J	2012	Cobalt	Body	Passenger Presence Module																																																												
J	2012	Cobalt	Body	Instrument Cluster																																																												
J	2012	Cobalt	Body	Radio																																																											
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																												
J	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																												
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2012	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2012	Cobalt	Body	Parking Assist Control Module																																																										
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission					V																																																				
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission					V																																																		V		
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																										
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								V		
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																								V		
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission					V																																																					
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission					V																																																					
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																										
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								V		
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								V		
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																								V		
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission					V																																																					
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission					V																																																					
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission					V																																																					
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission					V																																																					
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																								V		
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																										
J	2012	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2012	Cruze	Body	Body Control Module Hatchback																																																										
J	2012	Cruze	Body	Body Control Module Sedan																																																										
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2012	Cruze	Body	Passenger Presence Module																																																										
J	2012	Cruze	Body	Instrument Cluster																																																										
J	2012	Cruze	Body	Trailer Interface Control Module																																																										
J	2012	Cruze	Body	Radio																																																										
J	2012	Cruze	Body	Multimedia Player Interface Module																																																										
J	2012	Cruze	Body	Mobile Telephone Control Module																																																										
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																								
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																								
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																								
J	2012	Cruze	Body	Keyless Entry Control Module																																																								
J	2012	Cruze	Body	Parking Assist Control Module																																																								
J	2012	Cruze	Body	Steering Column Lock Control Module																																																								
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								V
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								V
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																					
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																								
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes													V																																											
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No													V																																											
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																								
J	2012	Sonic (First Gen)	Body	Remote Function Actuation																																								V																
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																								
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																								
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																								
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module Chassis Expansion CAN BUS																																																									
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module High Speed CAN Bus																																																									
J	2012	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																									
J	2012	Sonic (Second Gen)	Body	Body Control Module Sedan																																																									
J	2012	Sonic (Second Gen)	Body	Passenger Presence Module																																																									
J	2012	Sonic (Second Gen)	Body	Instrument Cluster																																																									
J	2012	Sonic (Second Gen)	Body	Radio																																																									
J	2012	Sonic (Second Gen)	Body	Telematic Vehicle Localization and Immobilization Control Module																																																									
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																									
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																									
J	2012	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																									
J	2012	Sonic (Second Gen)	Body	Parking Assist Control Module																																																									
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
J	2013	Aveo	Powertrain	Fuel Pump Control Module																																																									
J	2013	Aveo	Powertrain	Fuel Injector Control Module																																																									
J	2013	Aveo	Chassis	Electronic Brake Control Module																																																									
J	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2013	Aveo	Chassis	Electric Power Steering Control Module																																																									
J	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2013	Aveo	Body	Body Control Module Hatchback																																																									
J	2013	Aveo	Body	Body Control Module Sedan																																																									
J	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2013	Aveo	Body	Passenger Presence Module																																																									
J	2013	Aveo	Body	Instrument Cluster																																																									
J	2013	Aveo	Body	Radio																																																									
J	2013	Aveo	Body	Telematics Communication Interface Control Module																																																									
J	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
J	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
J	2013	Aveo	Body	Front Seat Heating Control Module																																																									
J	2013	Aveo	Body	Parking Assist Control Module																																																									
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2013	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Cobalt	Body	Body Control Module																																																										
J	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Cobalt	Body	Instrument Cluster																																																										
J	2013	Cobalt	Body	Radio																																																										
J	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																										
J	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2013	Cobalt	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission					V																																																					
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission					V																																																					
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission					V																																																					
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission					V																																																		V			
J	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission					V																																																					
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission					V																																																		V			
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																							V			
J	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																							V			
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission					V																																																					
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission					V																																																		V			
J	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																							V			
J	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																							V			
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																							V			

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission					V																																																					
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission					V																																																				V	
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission					V																																																					
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission					V																																																				V	
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission					V																																																					
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission					V																																																				V	
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									V	
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2013	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Cruze	Body	Body Control Module Hatchback																																																										
J	2013	Cruze	Body	Body Control Module Sedan																																																										
J	2013	Cruze	Body	Body Control Module Station Wagon																																																										
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Cruze	Body	Passenger Presence Module																																																										
J	2013	Cruze	Body	Instrument Cluster																																																										
J	2013	Cruze	Body	Trailer Interface Control Module																																																										
J	2013	Cruze	Body	Radio																																																										
J	2013	Cruze	Body	Digital Radio Receiver Control Module																																																										
J	2013	Cruze	Body	Multimedia Player Interface Module																																																										
J	2013	Cruze	Body	Mobile Telephone Control Module																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
J	2013	Cruze	Body	Front Seat Heating Control Module																																																										
J	2013	Cruze	Body	Keyless Entry Control Module																																																										
J	2013	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Body	Steering Column Lock Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										V
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										V
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																							
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes													V																																													
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No													V																																													
J	2013	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																											
J	2013	Sonic (First Gen)	Body	Remote Function Actuation																																									V																	
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																										
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission					V																																																				
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission					V																																																				
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																										
J	2013	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																										
J	2013	Sonic (Second Gen)	Body	Body Control Module Sedan																																																										
J	2013	Sonic (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Sonic (Second Gen)	Body	Passenger Presence Module																																																										
J	2013	Sonic (Second Gen)	Body	Instrument Cluster																																																										
J	2013	Sonic (Second Gen)	Body	Radio																																																										
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																										
J	2013	Sonic (Second Gen)	Body	Parking Assist Control Module																																																										
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2013	Spin	Chassis	Electronic Brake Control Module																																																										
J	2013	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Spin	Body	Body Control Module																																																										
J	2013	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Spin	Body	Instrument Cluster																																																										
J	2013	Spin	Body	Radio																																																										
J	2013	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Spin	Body	Parking Assist Control Module																																																										
J	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
J	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	Chassis Control Module																																																										
J	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Aveo	Chassis	Power Steering Control Module																																																										
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Aveo	Body	Body Control Module Hatchback																																																										
J	2014	Aveo	Body	Body Control Module Sedan																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Instrument Cluster																																																										
J	2014	Aveo	Body	Radio																																																										
J	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Aveo	Body	Front Seat Heating Control Module																																																										
J	2014	Aveo	Body	Keyless Entry Control Module																																																										
J	2014	Aveo	Body	Parking Assist Control Module																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2014	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Cobalt	Body	Body Control Module																																																										
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Cobalt	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2014	Cobalt	Body	Radio																																																										
J	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2014	Cobalt	Body	Parking Assist Control Module																																																										
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission					V																																																					
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission					V																																																	V			
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission					V																																																					
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission					V																																																	V			
J	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission					V																																																					
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission					V																																																	V			
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																						V			
J	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																						V			
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission					V																																																					
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission					V																																																	V			
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission					V																																																					
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission					V																																																	V			
J	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																						V			
J	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																						V			
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																						V			
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																						V			
J	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission					V																																																					
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission					V																																																	V			
J	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission					V																																																					
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission					V																																																	V			
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission					V																																																					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission					V																																																	V		
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																						V		
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																								
J	2014	Cruze	Powertrain	Fuel Injector Control Module																																																								
J	2014	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2014	Cruze	Chassis	Power Steering Control Module																																																								
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2014	Cruze	Body	Body Control Module Hatchback																																																								
J	2014	Cruze	Body	Body Control Module Sedan																																																								
J	2014	Cruze	Body	Body Control Module Station Wagon																																																								
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2014	Cruze	Body	Passenger Presence Module																																																								
J	2014	Cruze	Body	Instrument Cluster																																																								
J	2014	Cruze	Body	Trailer Interface Control Module																																																								
J	2014	Cruze	Body	Radio																																																								
J	2014	Cruze	Body	Digital Radio Receiver Control Module																																																								
J	2014	Cruze	Body	Multimedia Player Interface Module																																																								
J	2014	Cruze	Body	Mobile Telephone Control Module																																																								
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																								
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																								
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																								
J	2014	Cruze	Body	Front Seat Heating Control Module																																																								
J	2014	Cruze	Body	Keyless Entry Control Module																																																								
J	2014	Cruze	Body	Right Side Object Detection Control Module																																																								
J	2014	Cruze	Body	Left Side Object Detection Control Module																																																								
J	2014	Cruze	Body	Parking Assist Control Module																																																								
J	2014	Cruze	Body	Steering Column Lock Control Module																																																								
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module																																																								
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2014	Sonic	Powertrain	1.4L LDD Chassis Control Module																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Chassis Control Module																																																										
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission					V																																																				
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission					V																																																				
J	2014	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Chassis Control Module																																																										
J	2014	Sonic	Powertrain	Fuel Injector Control Module																																																										
J	2014	Sonic	Chassis	Electronic Brake Control Module																																																										
J	2014	Sonic	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Sonic	Chassis	Power Steering Control Module																																																										
J	2014	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Sonic	Body	Body Control Module Hatchback																																																										
J	2014	Sonic	Body	Body Control Module Sedan																																																										
J	2014	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Sonic	Body	Passenger Presence Module																																																										
J	2014	Sonic	Body	Instrument Cluster																																																										
J	2014	Sonic	Body	Radio																																																										
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Sonic	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Sonic	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Sonic	Body	Front Seat Heating Control Module																																																										
J	2014	Sonic	Body	Parking Assist Control Module																																																										
J	2014	Sonic	Body	Frontview Camera Module																																																										
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.5L L2B Transmission Control Module																																																										
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2014	Spin	Chassis	Electronic Brake Control Module																																																										
J	2014	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Spin	Body	Body Control Module																																																										
J	2014	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Spin	Body	Instrument Cluster																																																										
J	2014	Spin	Body	Radio																																																										
J	2014	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Spin	Body	Parking Assist Control Module																																																										
J	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
J	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
J	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2015	Aveo	Powertrain	Chassis Control Module																																																										
J	2015	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2015	Aveo	Chassis	Power Steering Control Module																																																										
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Aveo	Body	Body Control Module Hatchback																																																										
J	2015	Aveo	Body	Body Control Module Sedan																																																										
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Aveo	Body	Instrument Cluster																																																										
J	2015	Aveo	Body	Radio																																																										
J	2015	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Aveo	Body	Front Seat Heating Control Module																																																										
J	2015	Aveo	Body	Keyless Entry Control Module																																																										
J	2015	Aveo	Body	Parking Assist Control Module																																																										
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2015	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Cobalt	Body	Body Control Module																																																										
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Cobalt	Body	Instrument Cluster																																																										
J	2015	Cobalt	Body	Radio																																																										
J	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																										
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2015	Cobalt	Body	Parking Assist Control Module																																																										
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission					V																																																					
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission					V																																																		V		
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission					V																																																					
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission					V																																																		V		
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission					V																																																					
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission					V																																																		V		
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																							V		
J	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																							V		
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission					V																																																					
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission					V																																																		V		
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission					V																																																					
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission					V																																																		V		
J	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																							V		
J	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																							V		
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																							V		
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																							V		
J	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission					V																																																					
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission					V																																																		V		
J	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission					V																																																					
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission					V																																																			V		
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission					V																																																				
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission					V																																																		V		
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																							V		
J	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																									
J	2015	Cruze	Powertrain	Fuel Injector Control Module																																																									
J	2015	Cruze	Chassis	Electronic Brake Control Module																																																									
J	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2015	Cruze	Chassis	Power Steering Control Module																																																									
J	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2015	Cruze	Body	Body Control Module Hatchback																																																									
J	2015	Cruze	Body	Body Control Module Sedan																																																									
J	2015	Cruze	Body	Body Control Module Station Wagon																																																									
J	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2015	Cruze	Body	Passenger Presence Module																																																									
J	2015	Cruze	Body	Instrument Cluster																																																									
J	2015	Cruze	Body	Trailer Interface Control Module																																																									
J	2015	Cruze	Body	Radio																																																									
J	2015	Cruze	Body	Digital Radio Receiver Control Module																																																									
J	2015	Cruze	Body	Multimedia Player Interface Module																																																									
J	2015	Cruze	Body	Mobile Telephone Control Module																																																									
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																									
J	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																									
J	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																									
J	2015	Cruze	Body	Front Seat Heating Control Module																																																									
J	2015	Cruze	Body	Keyless Entry Control Module																																																									
J	2015	Cruze	Body	Right Side Object Detection Control Module																																																									
J	2015	Cruze	Body	Left Side Object Detection Control Module																																																									
J	2015	Cruze	Body	Parking Assist Control Module																																																									
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																									
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2015	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	1.6L LED Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission					V																																																					
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission					V																																																					
J	2015	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2015	Sonic	Powertrain	Chassis Control Module																																																											
J	2015	Sonic	Powertrain	Fuel Injector Control Module																																																											
J	2015	Sonic	Chassis	Electronic Brake Control Module																																																											
J	2015	Sonic	Chassis	Power Steering Control Module																																																											
J	2015	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2015	Sonic	Body	Body Control Module Hatchback																																																											
J	2015	Sonic	Body	Body Control Module Sedan																																																											
J	2015	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2015	Sonic	Body	Passenger Presence Module																																																											
J	2015	Sonic	Body	Instrument Cluster																																																											
J	2015	Sonic	Body	Radio																																																											
J	2015	Sonic	Body	Telematics Communication Interface Control Module																																																											
J	2015	Sonic	Body	HVAC Control Module Heater Only (C41)																																																											
J	2015	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2015	Sonic	Body	HVAC Control Module Single Zone (C60)																																																											
J	2015	Sonic	Body	Front Seat Heating Control Module																																																											
J	2015	Sonic	Body	Parking Assist Control Module																																																											
J	2015	Sonic	Body	Frontview Camera Module																																																											
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																											
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.5L L2B Transmission Control Module																																																											
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2015	Spin	Chassis	Electronic Brake Control Module																																																										
J	2015	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Spin	Body	Body Control Module																																																										
J	2015	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Spin	Body	Instrument Cluster																																																										
J	2015	Spin	Body	Radio																																																										
J	2015	Spin	Body	Telematics Communication Interface Control Module																																																										
J	2015	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Spin	Body	Front Seat Heating Control Module																																																										
J	2015	Spin	Body	Parking Assist Control Module																																																										
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
J	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
J	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
J	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2016	Aveo	Powertrain	Chassis Control Module																																																										
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2016	Aveo	Chassis	Power Steering Control Module																																																										
J	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Aveo	Body	Body Control Module Hatchback																																																										
J	2016	Aveo	Body	Body Control Module Sedan																																																										
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Aveo	Body	Instrument Cluster																																																										
J	2016	Aveo	Body	Radio																																																										
J	2016	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Aveo	Body	Front Seat Heating Control Module																																																										
J	2016	Aveo	Body	Parking Assist Control Module																																																										
J	2016	Aveo	Body	Keyless Entry Control Module																																																										
J	2016	Aveo	Body	Frontview Camera Module																																																										
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2016	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Cobalt	Body	Body Control Module																																																										
J	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Cobalt	Body	Instrument Cluster																																																										
J	2016	Cobalt	Body	Radio Other																																																										
J	2016	Cobalt	Body	Radio (IOB)																																																										
J	2016	Cobalt	Body	Radio (UF7)																																																										
J	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission					V																																																					
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission					V																																																			V		
J	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission					V																																																					
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission					V																																																			V		
J	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								V	
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission					V																																																				
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission					V																																																				
J	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
J	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																									
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																									
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																									
J	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								V	
J	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission					V																																																				
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission					V																																																				
J	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission					V																																																				
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission					V																																																		V	
J	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission					V																																																				
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission					V																																																		V	
J	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
J	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
J	2016	Cruze	Powertrain	Fuel Injector Control Module																																																									
J	2016	Cruze	Powertrain	Chassis Control Module																																																									
J	2016	Cruze	Chassis	Electronic Brake Control Module																																																									
J	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2016	Cruze	Chassis	Power Steering Control Module																																																									
J	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2016	Cruze	Body	Body Control Module Hatchback																																																									
J	2016	Cruze	Body	Body Control Module Sedan																																																									
J	2016	Cruze	Body	Body Control Module Station Wagon																																																									
J	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2016	Cruze	Body	Passenger Presence Module																																																									
J	2016	Cruze	Body	Instrument Cluster																																																									
J	2016	Cruze	Body	Trailer Interface Control Module																																																									
J	2016	Cruze	Body	Radio Other																																																									
J	2016	Cruze	Body	Radio (UF7)																																																									
J	2016	Cruze	Body	Multimedia Player Interface Module																																																									
J	2016	Cruze	Body	Mobile Telephone Control Module																																																									
J	2016	Cruze	Body	Telematics Communication Interface Control Module																																																									
J	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
J	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																									
J	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																									
J	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																									
J	2016	Cruze	Body	Front Seat Heating Control Module																																																									
J	2016	Cruze	Body	Keyless Entry Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2016	Cruze	Body	Right Side Object Detection Control Module																																																											
J	2016	Cruze	Body	Left Side Object Detection Control Module																																																											
J	2016	Cruze	Body	Parking Assist Control Module																																																											
J	2016	Cruze	Body	Steering Column Lock Control Module																																																											
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																											
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module																																																											
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission					V																																																						
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission					V																																																						
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2016	Sonic	Powertrain	Chassis Control Module																																																											
J	2016	Sonic	Powertrain	Fuel Injector Control Module																																																											
J	2016	Sonic	Chassis	Electronic Brake Control Module																																																											
J	2016	Sonic	Chassis	Power Steering Control Module																																																											
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Sonic	Body	Body Control Module Hatchback																																																											
J	2016	Sonic	Body	Body Control Module Sedan																																																											
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Sonic	Body	Passenger Presence Module																																																											
J	2016	Sonic	Body	Instrument Cluster																																																											
J	2016	Sonic	Body	Radio Other																																																										
J	2016	Sonic	Body	Radio (UF7)																																																											
J	2016	Sonic	Body	Radio (UH7)																																																											
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7																																																											
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Sonic	Body	Front Seat Heating Control Module																																																										
J	2016	Sonic	Body	Parking Assist Control Module																																																										
J	2016	Sonic	Body	Frontview Camera Module																																																										
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module																																																										
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2016	Spin	Chassis	Electronic Brake Control Module																																																										
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Spin	Body	Body Control Module																																																										
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Spin	Body	Instrument Cluster																																																										
J	2016	Spin	Body	Radio																																																										
J	2016	Spin	Body	Telematics Communication Interface Control Module																																																										
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Spin	Body	Front Seat Heating Control Module																																																										
J	2016	Spin	Body	Parking Assist Control Module																																																										
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										V
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																										V
K	2006	ALL	Powertrain	Transmission Control Module																																																										
K	2006	ALL	Chassis	Electronic Brake Control Module													V																																													
K	2006	ALL	Body	Remote Function Actuation																																								V																		
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										V
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																										V
K	2007	ALL	Powertrain	Transmission Control Module																																																										
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module													V																																													
K	2007	ALL	Chassis	Teves Electronic Brake Control Module													V																																													
K	2007	ALL	Body	Remote Function Actuation																																								V																		
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										V
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																										V
K	2008	ALL	Powertrain	Transmission Control Module																																																										
K	2008	ALL	Chassis	Electronic Brake Control Module													V																																													
K	2008	ALL	Body	Remote Function Actuation																																								V																		
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										V
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										V
K	2009	ALL	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2009	ALL	Chassis	Electronic Brake Control Module													V																																													
K	2009	ALL	Body	Remote Function Actuation																																									V																
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2010	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																							V	
K	2010	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																						V	
K	2010	ALL	Powertrain	Transmission Control Module																																																								
K	2010	ALL	Chassis	Electronic Brake Control Module													V																																												
K	2010	ALL	Body	Remote Function Actuation																																									V																
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2011	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																							V	
K	2011	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																						V	
K	2011	ALL	Powertrain	Transmission Control Module																																																								
K	2011	ALL	Chassis	Electronic Brake Control Module													V																																												
K	2011	ALL	Body	Remote Function Actuation																																									V																
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2012	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																							V	
K	2012	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																						V	
K	2012	ALL	Powertrain	Transmission Control Module																																																								
K	2012	ALL	Chassis	Electronic Brake Control Module													V																																												
K	2012	ALL	Body	Remote Function Actuation																																									V																
K	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2013	Onix	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																							V	
K	2013	Onix	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																							V	
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2013	Onix	Powertrain	Transmission Control Module																																																									
K	2013	Onix	Powertrain	Transmission Control Module																																																									
K	2013	Onix	Chassis	Electronic Brake Control Module																																																									
K	2013	Onix	Chassis	Electronic Brake Control Module													V																																												
K	2013	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																									
K	2013	Onix	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2013	Onix	Body	Body Control Module																																																									
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2013	Onix	Body	Instrument Cluster																																																									
K	2013	Onix	Body	Radio																																																									
K	2013	Onix	Body	Parking Assist Control Module																																																									
K	2013	Onix	Body	Remote Function Actuation																																									V																
K	2013	Prisma	Powertrain	Engine Control Module																																																									
K	2013	Prisma	Powertrain	Transmission Control Module																																																									
K	2013	Prisma	Chassis	Electronic Brake Control Module																																																									
K	2013	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																									
K	2013	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2013	Prisma	Body	Body Control Module																																																									
K	2013	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2013	Prisma	Body	Instrument Cluster																																																									
K	2013	Prisma	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2013	Prisma	Body	Parking Assist Control Module																																																											
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																												
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																												
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																												
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																												
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																												
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																												
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																												
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module																																																												
K	2014	Onix	Chassis	Electronic Brake Control Module																																																												
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2014	Onix	Body	Body Control Module																																																												
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Onix	Body	Instrument Cluster																																																												
K	2014	Onix	Body	Radio																																																												
K	2014	Onix	Body	Parking Assist Control Module																																																												
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																												
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																												
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module																																																												
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																												
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																												
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																												
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																												
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																												
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																												
K	2014	Prisma	Chassis	Electronic Brake Control Module																																																												
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2014	Prisma	Body	Body Control Module																																																												
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Prisma	Body	Instrument Cluster																																																												
K	2014	Prisma	Body	Radio																																																												
K	2014	Prisma	Body	Parking Assist Control Module																																																												
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																												
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																												
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																												
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																												
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																												
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																												
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																												
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module																																																												
K	2015	Onix	Chassis	Electronic Brake Control Module																																																												
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Onix	Body	Body Control Module																																																												
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Onix	Body	Instrument Cluster																																																												
K	2015	Onix	Body	Radio																																																												
K	2015	Onix	Body	Parking Assist Control Module																																																												
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																												
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2015	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2015	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Prisma	Body	Body Control Module																																																										
K	2015	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Prisma	Body	Instrument Cluster																																																										
K	2015	Prisma	Body	Radio																																																										
K	2015	Prisma	Body	Parking Assist Control Module																																																										
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2016	Onix	Chassis	Electronic Brake Control Module																																																										
K	2016	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Onix	Body	Body Control Module																																																										
K	2016	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Onix	Body	Instrument Cluster																																																										
K	2016	Onix	Body	Radio																																																										
K	2016	Onix	Body	Parking Assist Control Module																																																										
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2016	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2016	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Prisma	Body	Body Control Module																																																										
K	2016	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Prisma	Body	Instrument Cluster																																																										
K	2016	Prisma	Body	Radio																																																										
K	2016	Prisma	Body	HVAC Control Module																																																										
K	2016	Prisma	Body	Front Seat Heating Control Module																																																										
K	2016	Prisma	Body	Parking Assist Control Module																																																										
L	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
L	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										V
L	2004	ALL	Powertrain	Transmission Control Module																																																										
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes											V	V	V																																													
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control No													V																																													
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2004	ALL	Body	ISU																																								V				V											
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																							V	
L	2005	ALL	Powertrain	Transmission Control Module																																																								
L	2005	ALL	Chassis	Anti-lock Brake System													V																																											
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2005	ALL	Body	ISU																																								V				V											
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																							V	
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes													V																																											
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No													V																																											
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2006	ALL	Body	ISU																																								V				V											
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																							V	
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module			V																																																					
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																							V	
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																							V	
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector																																																								
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
L	2007	ALL	Chassis	Electronic Brake Control Module													V																																											
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2007	ALL	Body	ISU																																								V				V											
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module			V																																																				V	
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module			V																																																					
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module			V																																																				V	
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
L	2008	ALL	Chassis	Electronic Brake Control Module													V																																											
L	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2008	ALL	Body	ISU																																								V				V											
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module			V																																																				V	
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module			V																																																					
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module			V																																																				V	
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
L	2009	ALL	Chassis	Electronic Brake Control Module													V																																											
L	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2009	ALL	Body	ISU																																								V				V											
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module			V																																																				V	
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module			V																																																				V	
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module			V																																																					
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
L	2010	ALL	Chassis	Electronic Brake Control Module													V																																											
L	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2010	ALL	Body	ISU																																								V				V											
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module			V																																																				V	
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module			V																																																				V	

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module			V																																																							
L	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
L	2011	ALL	Chassis	Electronic Brake Control Module													V																																													
L	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2011	ALL	Body	ISU																																								V				V													
M	2004	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																						V																	V		
M	2004	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																						V																	V		
M	2004	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V																			
M	2004	ALL	Chassis	Anti-lock Brake System																																																										
M	2004	ALL	Body	Remote Function Actuation																																								V																		
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2005	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																						V			
M	2005	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2005	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2005	ALL	Chassis	Anti-lock Brake System																																																										
M	2005	ALL	Body	Remote Function Actuation																																								V																		
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																					V			
M	2006	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2006	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2006	ALL	Chassis	Anti-lock Brake System																																																										
M	2006	ALL	Body	Remote Function Actuation																																								V																		
M	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																					V			
M	2007	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2007	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2007	ALL	Chassis	Anti-lock Brake System																																																										
M	2007	ALL	Body	Remote Function Actuation																																								V																		
M	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																					V			
M	2008	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2008	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2008	ALL	Chassis	Anti-lock Brake System																																																										
M	2008	ALL	Body	Remote Function Actuation																																								V																		
M	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																					V			
M	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2009	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2009	ALL	Chassis	Anti-lock Brake System																																																										
M	2009	ALL	Body	Remote Function Actuation																																								V																		
M	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
M	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
M	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
M	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2010	Spark	Powertrain	Transmission Control Module																																																										
M	2010	Spark	Chassis	Electronic Brake Control Module																																																										
M	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2010	Spark	Chassis	Electric Power Steering Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
M	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2010	Spark	Body	Passenger Presence Module																																																										
M	2010	Spark	Body	Instrument Cluster																																																									
M	2011	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module					V																																																				
M	2011	Caprice	Powertrain	Transmission Control Module																																																									
M	2011	Caprice	Powertrain	Fuel Pump Control Module																																																									
M	2011	Caprice	Chassis	Electronic Brake Control Module													V																																												
M	2011	Caprice	Body	Body Control Module			V																													V			V																							
M	2011	Caprice	Body	HVAC Control Module																																																									
M	2011	Caprice	Body	Instrument Panel Cluster																																																									
M	2011	Caprice	Body	Passenger Presence System																																																									
M	2011	Caprice	Body	Radio																																																									
M	2011	Caprice	Body	Remote Control Door Lock Receiver																																																									
M	2011	Caprice	Body	Supplemental Inflatable Restraint																			V																																						
M	2011	Caprice	Body	Theft Deterrent Module		V																																																								
M	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
M	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
M	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
M	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										
M	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
M	2011	Spark	Powertrain	Transmission Control Module																																																										
M	2011	Spark	Chassis	Electronic Brake Control Module																																																										
M	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2011	Spark	Chassis	Electric Power Steering Control Module																																																										
M	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2011	Spark	Body	Passenger Presence Module																																																										
M	2011	Spark	Body	Instrument Cluster																																																										
M	2012	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module					V																																																				
M	2012	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module					V																																																				
M	2012	Caprice	Powertrain	Transmission Control Module																																																										
M	2012	Caprice	Powertrain	Fuel Pump Control Module																																																										
M	2012	Caprice	Chassis	Electronic Brake Control Module													V																																												
M	2012	Caprice	Body	Body Control Module			V																													V			V																							
M	2012	Caprice	Body	HVAC Control Module																																																									
M	2012	Caprice	Body	Instrument Panel Cluster																																																									
M	2012	Caprice	Body	Passenger Presence System																																																									
M	2012	Caprice	Body	Radio																																																									
M	2012	Caprice	Body	Remote Control Door Lock Receiver																																																									
M	2012	Caprice	Body	Supplemental Inflatable Restraint																																																									
M	2012	Caprice	Body	Theft Deterrent Module		V																																																							
M	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
M	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
M	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
M	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										
M	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
M	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
M	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
M	2012	Spark	Powertrain	Transmission Control Module																																																										
M	2012	Spark	Chassis	Electronic Brake Control Module																																																										
M	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2012	Spark	Chassis	Electric Power Steering Control Module																																																										
M	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2012	Spark	Body	Passenger Presence Module																																																										
M	2012	Spark	Body	Instrument Cluster																																																										
M	2013	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module					V																																																					
M	2013	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module					V																																																					
M	2013	Caprice	Powertrain	Transmission Control Module																																																										
M	2013	Caprice	Powertrain	Fuel Pump Control Module																																																										
M	2013	Caprice	Chassis	Electronic Brake Control Module													V																																													
M	2013	Caprice	Body	Body Control Module			V																													V			V																							
M	2013	Caprice	Body	HVAC Control Module																																																										
M	2013	Caprice	Body	Instrument Panel Cluster																																																										
M	2013	Caprice	Body	Passenger Presence System																																																										
M	2013	Caprice	Body	Radio																																																										
M	2013	Caprice	Body	Remote Control Door Lock Receiver																																																										
M	2013	Caprice	Body	Supplemental Inflatable Restraint																																																										
M	2013	Caprice	Body	Theft Deterrent Module		V																																																								
M	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										
M	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
M	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2013	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2013	Spark	Chassis	Electronic Brake Control Module																																																										
M	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2013	Spark	Chassis	Power Steering Control Module																																																										
M	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2013	Spark	Body	Body Control Module																																																										
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2013	Spark	Body	Passenger Presence Module																																																										
M	2013	Spark	Body	Instrument Cluster																																																										
M	2013	Spark	Body	Radio																																																										
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
M	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
M	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2014	Spark	Chassis	Power Steering Control Module																																																										
M	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2014	Spark	Body	Body Control Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Passenger Presence Module																																																										
M	2014	Spark	Body	Instrument Cluster																																																										
M	2014	Spark	Body	Radio																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark	Body	Keyless Entry Control Module																																																										
M	2014	Spark EV	Powertrain	Engine Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
M	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
M	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2014	Spark EV	Chassis	Power Steering Control Module																																																										
M	2014	Spark EV	Body	Body Control Module																																																										
M	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark EV	Body	Passenger Presence Module																																																										
M	2014	Spark EV	Body	Instrument Cluster																																																										
M	2014	Spark EV	Body	Radio																																																										
M	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
M	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2014	Spark EV	Body	Coolant Heater Control Module																																																										
M	2014	Spark EV	Body	Keyless Entry Control Module																																																										
M	2014	Spark EV	Body	Battery Charger Control Module																																																										
M	2014	Spark EV	Body	DC Charging Control Module																																																										
M	2014	Spark EV	Body	Battery Energy Control Module																																																										
M	2015	Matiz	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2015	Matiz	Chassis	Electronic Brake Control Module																																																										
M	2015	Matiz	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Matiz	Body	Keyless Entry Control Module																																																										
M	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
M	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
M	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2015	Spark	Chassis	Electronic Brake Control Module																																																										
M	2015	Spark	Chassis	Electronic Brake Control Module																																																										
M	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2015	Spark	Chassis	Power Steering Control Module																																																										
M	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2015	Spark	Body	Body Control Module																																																										
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Spark	Body	Passenger Presence Module																																																										
M	2015	Spark	Body	Instrument Cluster																																																										
M	2015	Spark	Body	Instrument Cluster																																																										
M	2015	Spark	Body	Tire Pressure Indicator Module																																																										
M	2015	Spark	Body	Radio																																																										
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2015	Spark	Body	Keyless Entry Control Module																																																										
M	2015	Spark EV	Powertrain	Engine Control Module																																																										
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
M	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
M	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2015	Spark EV	Chassis	Power Steering Control Module																																																										
M	2015	Spark EV	Body	Body Control Module																																																										
M	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Spark EV	Body	Passenger Presence Module																																																										
M	2015	Spark EV	Body	Instrument Cluster																																																										
M	2015	Spark EV	Body	Radio																																																										
M	2015	Spark EV	Body	HVAC Control Module																																																										
M	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2015	Spark EV	Body	Coolant Heater Control Module																																																										
M	2015	Spark EV	Body	Keyless Entry Control Module																																																										
M	2015	Spark EV	Body	Battery Charger Control Module																																																										
M	2015	Spark EV	Body	DC Charging Control Module																																																										
M	2015	Spark EV	Body	Battery Energy Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2016	Spark	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2016	Spark	Chassis	Power Steering Control Module																																																										
M	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2016	Spark	Body	Body Control Module																																																										
M	2016	Spark	Body	Body Control Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Instrument Cluster																																																										
M	2016	Spark	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
M	2016	Spark	Body	Radio																																																										
M	2016	Spark	Body	Telematics Communication Interface Control Module																																																										
M	2016	Spark	Body	Keyless Entry Control Module																																																										
M	2016	Spark EV	Powertrain	Engine Control Module																																																										
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
M	2016	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
M	2016	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2016	Spark EV	Chassis	Power Steering Control Module																																																										
M	2016	Spark EV	Body	Body Control Module																																																										
M	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark EV	Body	Passenger Presence Module																																																										
M	2016	Spark EV	Body	Instrument Cluster																																																										
M	2016	Spark EV	Body	Radio																																																										
M	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
M	2016	Spark EV	Body	HVAC Control Module																																																										
M	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2016	Spark EV	Body	Coolant Heater Control Module																																																										
M	2016	Spark EV	Body	Keyless Entry Control Module																																																										
M	2016	Spark EV	Body	Frontview Camera Module																																																										
M	2016	Spark EV	Body	Battery Charger Control Module																																																										
M	2016	Spark EV	Body	DC Charging Control Module																																																										
M	2016	Spark EV	Body	Battery Energy Control Module																																																										
N	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
N	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2004	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes										V	V	V																																														
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control No												V																																														
N	2004	Optra	Body	Remote Function Actuation																																									V																	
N	2004	Optra	Body	Supplemental Inflatable Restraint																																																										
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module					V																																																					
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
N	2004	Classic	Chassis	Anti-lock Brake System																																																										
N	2004	Classic	Body	Body Control Module																																																										
N	2004	Classic	Body	Radio																																																										
N	2004	Classic	Body	Remote Function Actuation																																									V																	
N	2004	Classic	Body	Supplemental Inflatable Restraint																V																																										
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Engine Control Module					V																																																					
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Transmission Control Module																																																										
N	2004	Alero (Export)	Chassis	Anti-lock Brake System																																																										
N	2004	Alero (Export)	Body	Body Control Module																																																										
N	2004	Alero (Export)	Body	Instrument Panel Cluster																																																										
N	2004	Alero (Export)	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
N	2004	Alero (Export)	Body	Supplemental Inflatable Restraint																	V																																								
N	2004	Alero (Export)	Body	Vehicle Theft Deterrent																																																									
N	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V																V	
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																						V	
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																							
N	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																							
N	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																						
N	2005	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																						
N	2005	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																						
N	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																						
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes											V	V	V																																									
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control No													V																																									
N	2005	Optra	Body	Remote Function Actuation																																								V														
N	2005	Optra	Body	Supplemental Inflatable Restraint																																																						
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module					V																																																	
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																						
N	2005	Classic	Chassis	Anti-lock Brake System																																																						
N	2005	Classic	Body	Body Control Module																																																						
N	2005	Classic	Body	Radio																																																						
N	2005	Classic	Body	Remote Function Actuation																																								V														
N	2005	Classic	Body	Supplemental Inflatable Restraint																																																					
N	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																					V	
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																					V	
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																						
N	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																						
N	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																						
N	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																						
N	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																						
N	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																						
N	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																						
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes											V	V	V																																									
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No													V																																									
N	2006	ALL	Body	Remote Function Actuation																																								V														
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																					
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																						
N	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																					V	
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																					V	
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																						
N	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																						
N	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																						
N	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																			
N	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module			V																																																			
N	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																						
N	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																						
N	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																						
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes											V	V	V																																									
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No													V																																									
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes													V																																									
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No													V																																									
N	2007	ALL	Chassis	Tire Pressure Monitor																																																						
N	2007	ALL	Body	Remote Function Actuation																																								V														

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
N	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																							V	
N	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																						V	
N	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																						V	
N	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																							
N	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																							
N	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																				
N	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module			V																																																				
N	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																							
N	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																							
N	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																							
N	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																							
N	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																							
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes													V																																										
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No													V																																										
N	2008	ALL	Chassis	Tire Pressure Monitor																																																							
N	2008	ALL	Body	Remote Function Actuation																																								V															
N	2008	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																							V	
N	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																							V	
N	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																							V	
N	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																						
N	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																						
N	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																			
N	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																						
N	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																						
N	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																						
N	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																						
N	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																						
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes													V																																										
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No													V																																										
N	2009	ALL	Chassis	Tire Pressure Monitor																																																						
N	2009	ALL	Body	Remote Function Actuation																																								V															
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																						
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																						
N	2010	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																							V	
N	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																							V	
N	2010	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																						
N	2010	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																			
N	2010	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																						
N	2010	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																						
N	2010	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																						
N	2010	ALL	Powertrain	Transmission Control Module 5 Speed																																																						
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control Yes													V																																										
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control No													V																																										
N	2010	ALL	Chassis	Tire Pressure Monitor																																																						
N	2010	ALL	Body	Remote Function Actuation																																								V															
N	2010	ALL	Body	Remote Function Actuation																																																						
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																						
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																						
N	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																						V	

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
N	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								V	
N	2011	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
N	2011	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																					
N	2011	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
N	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2011	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
N	2011	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control Yes													V																																										
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control No													V																																										
N	2011	ALL	Chassis	Tire Pressure Monitor																																																								
N	2011	ALL	Body	Remote Function Actuation																																								V															
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2012	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								V
N	2012	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								V
N	2012	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
N	2012	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																					
N	2012	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2012	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
N	2012	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control Yes													V																																										
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control No													V																																										
N	2012	ALL	Chassis	Tire Pressure Monitor																																																								
N	2012	ALL	Body	Remote Function Actuation																																								V															
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2013	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								V
N	2013	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								V
N	2013	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
N	2013	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module			V																																																				
N	2013	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2013	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
N	2013	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control Yes													V																																										
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control No													V																																										
N	2013	ALL	Chassis	Tire Pressure Monitor																																																								
N	2013	ALL	Body	Remote Function Actuation																																								V															
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
N	2014	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																								
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																								
N	2014	Caprice	Powertrain	(2) 6.0L L77 Chassis Control Module																																																								
N	2014	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																								
N	2014	Caprice	Chassis	Electronic Brake Control Module																																																								
N	2014	Caprice	Chassis	Parking Brake Control Module																																																								
N	2014	Caprice	Chassis	Power Steering Control Module																																																								
N	2014	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																								
N	2014	Caprice	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
N	2014	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2014	Caprice	Body	Passenger Presence Module																																																											
N	2014	Caprice	Body	Instrument Cluster																																																										
N	2014	Caprice	Body	Radio Controls																																																										
N	2014	Caprice	Body	HVAC Controls																																																										
N	2014	Caprice	Body	Headlamp Control Module																																																										
N	2014	Caprice	Body	Trailer Interface Control Module																																																										
N	2014	Caprice	Body	Radio																																																										
N	2014	Caprice	Body	HVAC Control Module																																																										
N	2014	Caprice	Body	Parking Assist Control Module																																																										
N	2014	Caprice	Body	Frontview Camera Module																																																										
N	2014	Caprice	Body	Steering Column Lock Control Module																																																										
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
N	2015	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
N	2015	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
N	2015	Caprice	Powertrain	Fuel Injector Control Module																																																										
N	2015	Caprice	Chassis	Electronic Brake Control Module																																																										
N	2015	Caprice	Chassis	Parking Brake Control Module																																																										
N	2015	Caprice	Chassis	Power Steering Control Module																																																										
N	2015	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2015	Caprice	Chassis	Suspension Control Module																																																										
N	2015	Caprice	Body	Body Control Module																																																										
N	2015	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2015	Caprice	Body	Passenger Presence Module																																																										
N	2015	Caprice	Body	Instrument Cluster																																																										
N	2015	Caprice	Body	Head-Up Display Module																																																										
N	2015	Caprice	Body	Radio Controls																																																										
N	2015	Caprice	Body	HVAC Controls																																																										
N	2015	Caprice	Body	Headlamp Control Module																																																										
N	2015	Caprice	Body	Trailer Interface Control Module																																																										
N	2015	Caprice	Body	Radio																																																										
N	2015	Caprice	Body	Telematics Communication Interface Control Module																																																										
N	2015	Caprice	Body	HVAC Control Module																																																										
N	2015	Caprice	Body	Right Side Object Detection Control Module																																																										
N	2015	Caprice	Body	Left Side Object Detection Control Module																																																										
N	2015	Caprice	Body	Parking Assist Control Module																																																										
N	2015	Caprice	Body	Frontview Camera Module																																																										
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
N	2016	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
N	2016	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
N	2016	Caprice	Powertrain	Fuel Injector Control Module																																																										
N	2016	Caprice	Chassis	Electronic Brake Control Module																																																										
N	2016	Caprice	Chassis	Parking Brake Control Module																																																										
N	2016	Caprice	Chassis	Power Steering Control Module																																																										
N	2016	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
N	2016	Caprice	Chassis	Suspension Control Module																																																										
N	2016	Caprice	Body	Body Control Module																																																										
N	2016	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2016	Caprice	Body	Passenger Presence Module																																																										
N	2016	Caprice	Body	Instrument Cluster																																																										
N	2016	Caprice	Body	Head-Up Display Module																																																										
N	2016	Caprice	Body	Radio Controls																																																										
N	2016	Caprice	Body	HVAC Controls																																																										
N	2016	Caprice	Body	Trailer Interface Control Module																																																										
N	2016	Caprice	Body	Radio																																																										
N	2016	Caprice	Body	Telematics Communication Interface Control Module																																																										
N	2016	Caprice	Body	HVAC Control Module																																																										
N	2016	Caprice	Body	Seat Memory Control Module - Driver																																																										
N	2016	Caprice	Body	Right Side Object Detection Control Module																																																										
N	2016	Caprice	Body	Left Side Object Detection Control Module																																																										
N	2016	Caprice	Body	Parking Assist Control Module																																																										
N	2016	Caprice	Body	Frontview Camera Module																																																										
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																										
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																									V	
P	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																										
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																										
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																									V	
P	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																										
P	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																										
P	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																									V	
P	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																										
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																										
P	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																										
P	2010	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2010	Cruze	Body	Body Control Module																																																										
P	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2010	Cruze	Body	Passenger Presence Module																																																										
P	2010	Cruze	Body	Instrument Cluster																																																										
P	2010	Cruze	Body	Trailer Interface Control Module																																																										
P	2010	Cruze	Body	Radio																																																										
P	2010	Cruze	Body	Multimedia Player Interface Module																																																										
P	2010	Cruze	Body	Mobile Telephone Control Module																																																										
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
P	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
P	2010	Cruze	Body	Keyless Entry Control Module																																																										
P	2010	Cruze	Body	Parking Assist Control Module																																																										
P	2010	Cruze	Body	Steering Column Lock Control Module																																																										
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission					V																																																				
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission					V																																																			V	
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																										
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																							V		
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																								
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																							V		
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission					V																																																				
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission					V																																																				
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																									
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																							V		
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																							V		
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission					V																																																				
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission					V																																																				
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission					V																																																				
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission					V																																																				
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																									
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																									
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																									
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																							V		
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2011	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2011	Cruze	Body	Body Control Module																																																									
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2011	Cruze	Body	Passenger Presence Module																																																									
P	2011	Cruze	Body	Instrument Cluster																																																									
P	2011	Cruze	Body	Trailer Interface Control Module																																																									
P	2011	Cruze	Body	Radio																																																									
P	2011	Cruze	Body	Multimedia Player Interface Module																																																									
P	2011	Cruze	Body	Mobile Telephone Control Module																																																									
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
P	2011	Cruze	Body	Keyless Entry Control Module																																																									
P	2011	Cruze	Body	Parking Assist Control Module																																																									
P	2011	Cruze	Body	Steering Column Lock Control Module																																																									
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission					V																																																				
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission					V																																																		V		
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																									
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								V		

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
P	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																										
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																								V	
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission					V																																																				
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission					V																																																				
P	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																									
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								V	
P	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								V	
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																								V	
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission					V																																																				
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission					V																																																				
P	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission					V																																																				
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission					V																																																				
P	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																								V	
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																									
P	2012	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2012	Cruze	Body	Body Control Module Hatchback																																																									
P	2012	Cruze	Body	Body Control Module Sedan																																																									
P	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2012	Cruze	Body	Passenger Presence Module																																																									
P	2012	Cruze	Body	Instrument Cluster																																																									
P	2012	Cruze	Body	Trailer Interface Control Module																																																									
P	2012	Cruze	Body	Radio																																																									
P	2012	Cruze	Body	Multimedia Player Interface Module																																																									
P	2012	Cruze	Body	Mobile Telephone Control Module																																																									
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
P	2012	Cruze	Body	Keyless Entry Control Module																																																									
P	2012	Cruze	Body	Parking Assist Control Module																																																									
P	2012	Cruze	Body	Steering Column Lock Control Module																																																									
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission					V																																																				
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission					V																																																				
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission					V																																																				

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission					V																																																	V		
P	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																								
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission					V																																																			
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission					V																																																		V		
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																								
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																								
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																							V		
P	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																								
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																							V		
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission					V																																																			
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission					V																																																		V		
P	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																							V		
P	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																							V		
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																							V		
P	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission					V																																																			
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission					V																																																		V		
P	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission					V																																																			
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission					V																																																		V		
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																								
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																								
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission					V																																																			
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission					V																																																		V		
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																								
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																							V		
P	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2013	Cruze	Chassis	Electronic Brake Control Module																																																								
P	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2013	Cruze	Body	Body Control Module Hatchback																																																								
P	2013	Cruze	Body	Body Control Module Sedan																																																								
P	2013	Cruze	Body	Body Control Module Station Wagon																																																								
P	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2013	Cruze	Body	Passenger Presence Module																																																								
P	2013	Cruze	Body	Instrument Cluster																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
P	2013	Cruze	Body	Trailer Interface Control Module																																																										
P	2013	Cruze	Body	Radio																																																										
P	2013	Cruze	Body	Digital Radio Receiver Control Module																																																										
P	2013	Cruze	Body	Multimedia Player Interface Module																																																										
P	2013	Cruze	Body	Mobile Telephone Control Module																																																										
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
P	2013	Cruze	Body	Front Seat Heating Control Module																																																										
P	2013	Cruze	Body	Keyless Entry Control Module																																																										
P	2013	Cruze	Body	Right Side Object Detection Control Module																																																										
P	2013	Cruze	Body	Left Side Object Detection Control Module																																																										
P	2013	Cruze	Body	Parking Assist Control Module																																																										
P	2013	Cruze	Body	Steering Column Lock Control Module																																																										
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission					V																																																					
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission					V																																																		V		
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission					V																																																					
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission					V																																																		V		
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission					V																																																					
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission					V																																																		V		
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																							V		
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								V		
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission					V																																																					
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission					V																																																		V		
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission					V																																																					
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission					V																																																		V		
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								V		
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																								V		
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								V		
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								V		
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission					V																																																					
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission					V																																																		V		
P	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission					V																																																				
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission					V																																																		V		
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																									
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission					V																																																				
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission					V																																																		V		
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																									
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																							V		
P	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																									
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																									
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																									
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																									
P	2014	Cruze	Powertrain	Fuel Injector Control Module																																																									
P	2014	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2014	Cruze	Chassis	Power Steering Control Module																																																									
P	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2014	Cruze	Body	Body Control Module Hatchback																																																									
P	2014	Cruze	Body	Body Control Module Sedan																																																									
P	2014	Cruze	Body	Body Control Module Station Wagon																																																									
P	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2014	Cruze	Body	Passenger Presence Module																																																									
P	2014	Cruze	Body	Instrument Cluster																																																									
P	2014	Cruze	Body	Trailer Interface Control Module																																																									
P	2014	Cruze	Body	Radio																																																									
P	2014	Cruze	Body	Digital Radio Receiver Control Module																																																									
P	2014	Cruze	Body	Multimedia Player Interface Module																																																									
P	2014	Cruze	Body	Mobile Telephone Control Module																																																									
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																									
P	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																									
P	2014	Cruze	Body	Front Seat Heating Control Module																																																									
P	2014	Cruze	Body	Keyless Entry Control Module																																																									
P	2014	Cruze	Body	Right Side Object Detection Control Module																																																									
P	2014	Cruze	Body	Left Side Object Detection Control Module																																																									
P	2014	Cruze	Body	Parking Assist Control Module																																																									
P	2014	Cruze	Body	Steering Column Lock Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission					V																																																				
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission					V																																																		V		
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission					V																																																				
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission					V																																																			V		
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission					V																																																				
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission					V																																																			V		
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								V		
P	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								V		
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission					V																																																				
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission					V																																																			V		
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission					V																																																				
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission					V																																																			V		
P	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								V		
P	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																								V		
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								V		
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								V		
P	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission					V																																																				
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission					V																																																			V		
P	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission					V																																																				
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission					V																																																			V		
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission					V																																																				
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission					V																																																			V		

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																							V		
P	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																										
P	2015	Cruze	Powertrain	Fuel Injector Control Module																																																										
P	2015	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2015	Cruze	Chassis	Power Steering Control Module																																																										
P	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2015	Cruze	Body	Body Control Module Hatchback																																																										
P	2015	Cruze	Body	Body Control Module Sedan																																																										
P	2015	Cruze	Body	Body Control Module Station Wagon																																																										
P	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2015	Cruze	Body	Passenger Presence Module																																																										
P	2015	Cruze	Body	Instrument Cluster																																																										
P	2015	Cruze	Body	Trailer Interface Control Module																																																										
P	2015	Cruze	Body	Radio																																																										
P	2015	Cruze	Body	Digital Radio Receiver Control Module																																																										
P	2015	Cruze	Body	Multimedia Player Interface Module																																																										
P	2015	Cruze	Body	Mobile Telephone Control Module																																																										
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
P	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
P	2015	Cruze	Body	Front Seat Heating Control Module																																																										
P	2015	Cruze	Body	Keyless Entry Control Module																																																										
P	2015	Cruze	Body	Right Side Object Detection Control Module																																																										
P	2015	Cruze	Body	Left Side Object Detection Control Module																																																										
P	2015	Cruze	Body	Parking Assist Control Module																																																										
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission					V																																																					
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission					V																																																		V		
P	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission					V																																																					
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission					V																																																		V		
P	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								V		
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission					V																																																					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission					V																																																				
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								V		
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission					V																																																				
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission					V																																																				
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission					V																																																				
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission					V																																																		V		
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission					V																																																				
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission					V																																																		V		
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2016	Cruze	Powertrain	Fuel Injector Control Module																																																										
P	2016	Cruze	Powertrain	Chassis Control Module																																																										
P	2016	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2016	Cruze	Chassis	Power Steering Control Module																																																										
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2016	Cruze	Body	Body Control Module Hatchback																																																										
P	2016	Cruze	Body	Body Control Module Sedan																																																										
P	2016	Cruze	Body	Body Control Module Station Wagon																																																										
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2016	Cruze	Body	Passenger Presence Module																																																										
P	2016	Cruze	Body	Instrument Cluster																																																										
P	2016	Cruze	Body	Trailer Interface Control Module																																																										
P	2016	Cruze	Body	Radio Other																																																										
P	2016	Cruze	Body	Radio (UF7)																																																										
P	2016	Cruze	Body	Multimedia Player Interface Module																																																										
P	2016	Cruze	Body	Mobile Telephone Control Module																																																										
P	2016	Cruze	Body	Telematics Communication Interface Control Module																																																										
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																										
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																										
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																										
P	2016	Cruze	Body	Front Seat Heating Control Module																																																										
P	2016	Cruze	Body	Keyless Entry Control Module																																																										
P	2016	Cruze	Body	Right Side Object Detection Control Module																																																										
P	2016	Cruze	Body	Left Side Object Detection Control Module																																																										
P	2016	Cruze	Body	Parking Assist Control Module																																																										
P	2016	Cruze	Body	Steering Column Lock Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2011	Volt	Powertrain	Engine Control Module																																																										
R	2011	Volt	Powertrain	Trasmission Control Module																																																											
R	2011	Volt	Powertrain	Fuel Pump Control Module																																																											
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module																																																											
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2011	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2011	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2011	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2011	Volt	Chassis	Electronic Brake Control Module																																																											
R	2011	Volt	Chassis	Parking Brake Control Module																																																											
R	2011	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
R	2011	Volt	Chassis	Power Steering Control Module																																																											
R	2011	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2011	Volt	Body	Body Control Module																																																											
R	2011	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2011	Volt	Body	Passenger Presence Module																																																											
R	2011	Volt	Body	Instrument Cluster																																																											
R	2011	Volt	Body	Radio																																																											
R	2011	Volt	Body	Digital Radio Receiver Control Module																																																											
R	2011	Volt	Body	Mobile Telephone Control Module																																																											
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2011	Volt	Body	Remote Heater and Air Conditioning Control Module																																																											
R	2011	Volt	Body	Electric A/C Compressor Control Module																																																											
R	2011	Volt	Body	Coolant Heater Control Module																																																											
R	2011	Volt	Body	Keyless Entry Control Module																																																											
R	2011	Volt	Body	Parking Assist Control Module																																																											
R	2011	Volt	Body	Steering Column Lock Control Module																																																											
R	2011	Volt	Body	Battery Charger Control Module																																																											
R	2011	Volt	Body	Battery Energy Control Module																																																											
R	2012	Volt	Powertrain	Engine Control Module																																																											
R	2012	Volt	Powertrain	Trasmission Control Module																																																											
R	2012	Volt	Powertrain	Fuel Pump Control Module																																																											
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module																																																											
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2012	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2012	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2012	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2012	Volt	Chassis	Electronic Brake Control Module																																																											
R	2012	Volt	Chassis	Parking Brake Control Module																																																											
R	2012	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
R	2012	Volt	Chassis	Power Steering Control Module																																																											
R	2012	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2012	Volt	Body	Body Control Module																																																											
R	2012	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2012	Volt	Body	Passenger Presence Module																																																											
R	2012	Volt	Body	Instrument Cluster																																																											
R	2012	Volt	Body	Radio																																																											
R	2012	Volt	Body	Digital Radio Receiver Control Module																																																											
R	2012	Volt	Body	Mobile Telephone Control Module																																																											
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 9																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2012	Volt	Body	Remote Heater and Air Conditioning Control Module																																																										
R	2012	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2012	Volt	Body	Coolant Heater Control Module																																																										
R	2012	Volt	Body	Keyless Entry Control Module																																																										
R	2012	Volt	Body	Parking Assist Control Module																																																										
R	2012	Volt	Body	Steering Column Lock Control Module																																																										
R	2012	Volt	Body	Battery Charger Control Module																																																										
R	2012	Volt	Body	Battery Energy Control Module																																																										
R	2013	Volt	Powertrain	Engine Control Module																																																										
R	2013	Volt	Powertrain	Trasmission Control Module																																																										
R	2013	Volt	Powertrain	Fuel Pump Control Module																																																										
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2013	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2013	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2013	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2013	Volt	Chassis	Electronic Brake Control Module																																																										
R	2013	Volt	Chassis	Parking Brake Control Module																																																										
R	2013	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2013	Volt	Chassis	Power Steering Control Module																																																										
R	2013	Volt	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2013	Volt	Body	Body Control Module																																																										
R	2013	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2013	Volt	Body	Passenger Presence Module																																																										
R	2013	Volt	Body	Instrument Cluster																																																										
R	2013	Volt	Body	Radio																																																										
R	2013	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2013	Volt	Body	Multimedia Player Interface Module																																																										
R	2013	Volt	Body	Mobile Telephone Control Module																																																										
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2013	Volt	Body	HVAC Control Module																																																										
R	2013	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2013	Volt	Body	Coolant Heater Control Module																																																										
R	2013	Volt	Body	Front Seat Heating Control Module																																																										
R	2013	Volt	Body	Keyless Entry Control Module																																																										
R	2013	Volt	Body	Parking Assist Control Module																																																										
R	2013	Volt	Body	Frontview Camera Module																																																										
R	2013	Volt	Body	Steering Column Lock Control Module																																																										
R	2013	Volt	Body	Battery Charger Control Module																																																										
R	2013	Volt	Body	Battery Energy Control Module																																																										
R	2014	Volt	Powertrain	Engine Control Module																																																										
R	2014	Volt	Powertrain	Trasmission Control Module																																																										
R	2014	Volt	Powertrain	Chassis Control Module																																																										
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2014	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2014	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2014	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2014	Volt	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2014	Volt	Chassis	Parking Brake Control Module																																																										
R	2014	Volt	Chassis	Power Steering Control Module																																																											
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2014	Volt	Body	Body Control Module																																																											
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2014	Volt	Body	Passenger Presence Module																																																											
R	2014	Volt	Body	Instrument Cluster																																																											
R	2014	Volt	Body	Radio																																																											
R	2014	Volt	Body	Digital Radio Receiver Control Module																																																											
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2014	Volt	Body	HVAC Control Module																																																											
R	2014	Volt	Body	Electric A/C Compressor Control Module																																																											
R	2014	Volt	Body	Coolant Heater Control Module																																																											
R	2014	Volt	Body	Front Seat Heating Control Module																																																											
R	2014	Volt	Body	Keyless Entry Control Module																																																											
R	2014	Volt	Body	Parking Assist Control Module																																																											
R	2014	Volt	Body	Frontview Camera Module																																																											
R	2014	Volt	Body	Steering Column Lock Control Module																																																											
R	2014	Volt	Body	Battery Charger Control Module																																																											
R	2014	Volt	Body	Battery Energy Control Module																																																											
R	2015	Volt	Powertrain	Engine Control Module																																																											
R	2015	Volt	Powertrain	Trasmission Control Module																																																											
R	2015	Volt	Powertrain	Chassis Control Module																																																											
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module																																																											
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2015	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2015	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2015	Volt	Chassis	Electronic Brake Control Module																																																											
R	2015	Volt	Chassis	Parking Brake Control Module																																																											
R	2015	Volt	Chassis	Power Steering Control Module																																																											
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2015	Volt	Body	Body Control Module																																																											
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2015	Volt	Body	Passenger Presence Module																																																											
R	2015	Volt	Body	Instrument Cluster																																																											
R	2015	Volt	Body	Radio																																																											
R	2015	Volt	Body	Digital Radio Receiver Control Module																																																											
R	2015	Volt	Body	Telematics Communication Interface Control Module																																																											
R	2015	Volt	Body	HVAC Control Module																																																											
R	2015	Volt	Body	Electric A/C Compressor Control Module																																																											
R	2015	Volt	Body	Coolant Heater Control Module																																																											
R	2015	Volt	Body	Front Seat Heating Control Module																																																											
R	2015	Volt	Body	Keyless Entry Control Module																																																											
R	2015	Volt	Body	Parking Assist Control Module																																																											
R	2015	Volt	Body	Frontview Camera Module																																																											
R	2015	Volt	Body	Steering Column Lock Control Module																																																											
R	2015	Volt	Body	Battery Charger Control Module																																																											
R	2015	Volt	Body	Battery Energy Control Module																																																											
R	2016	Volt	Powertrain	Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2016	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2016	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2016	Volt	Chassis	Electronic Brake Control Module																																																										
R	2016	Volt	Chassis	Brake Booster Control Module																																																										
R	2016	Volt	Chassis	Power Steering Control Module																																																										
R	2016	Volt	Body	Body Control Module																																																										
R	2016	Volt	Body	Pedestrian Alert Sound Control Module																																																										
R	2016	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Volt	Body	Passenger Presence Module																																																										
R	2016	Volt	Body	Instrument Cluster																																																										
R	2016	Volt	Body	Radio Controls																																																										
R	2016	Volt	Body	HVAC Controls																																																										
R	2016	Volt	Body	Radio																																																										
R	2016	Volt	Body	Amplifier																																																										
R	2016	Volt	Body	Human Machine Interface Control Module																																																										
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 9.7																																																										
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2016	Volt	Body	HVAC Control Module																																																										
R	2016	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2016	Volt	Body	Keyless Entry Control Module																																																										
R	2016	Volt	Body	Right Side Object Detection Control Module																																																										
R	2016	Volt	Body	Left Side Object Detection Control Module																																																										
R	2016	Volt	Body	Parking Assist Control Module																																																										
R	2016	Volt	Body	Frontview Camera Module																																																										
R	2016	Volt	Body	Steering Column Lock Control Module																																																										
R	2016	Volt	Body	Battery Energy Control Module																																																										
R	2016	Volt	Body	Long Range Radar Sensor Module																																																										
S	2004	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2004	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																							V																	V	
S	2004	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2004	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
S	2004	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2004	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
S	2004	Aveo	Powertrain	Transmission Control Module																																																										
S	2004	Aveo	Chassis	Electronic Brake Control Module													V																																												
S	2004	Aveo	Chassis	Electronic Brake Control Module													V																																												
S	2004	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2004	Aveo	Body	Remote Function Actuation																																								V																	
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2005	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																							V																	V	
S	2005	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2005	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
S	2005	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2005	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
S	2005	Aveo	Powertrain	Transmission Control Module																																																										
S	2005	Aveo	Chassis	Electronic Brake Control Module													V																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2005	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2005	Aveo	Body	Remote Function Actuation																																									V																	
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2006	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								V		
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
S	2006	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
S	2006	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module			V																																																							
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
S	2006	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2006	Aveo	Chassis	Electronic Brake Control Module													V																																													
S	2006	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2006	Aveo	Body	Remote Function Actuation																																									V																	
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2007	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								V		
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
S	2007	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
S	2007	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module			V																																																							
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
S	2007	Aveo	Powertrain	Transmission Control Module 4 Speed																																																										
S	2007	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2007	Aveo	Chassis	Electronic Brake Control Module													V																																													
S	2007	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2007	Aveo	Body	Remote Function Actuation																																									V																	
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2008	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																								V		
S	2008	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																							V		
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
S	2008	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2008	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2008	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
S	2008	Aveo	Powertrain	Transmission Control Module																																																										
S	2008	Aveo	Powertrain	Transmission Control Module																																																										
S	2008	Aveo	Chassis	Electronic Brake Control Module													V																																													
S	2008	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2008	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2008	Aveo	Body	Remote Function Actuation																																									V																	
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2009	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																								V		
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
S	2009	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2009	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2009	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module					V																																																	V		V
S	2009	Aveo	Powertrain	Transmission Control Module																																																								
S	2009	Aveo	Powertrain	Transmission Control Module																																																								
S	2009	Aveo	Powertrain	Other Auto Transmission System																																																								
S	2009	Aveo	Chassis	Electronic Brake Control Module													V																																										
S	2009	Aveo	Chassis	Tire Pressure Monitor																																																								
S	2009	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2009	Aveo	Body	Remote Function Actuation																																									V															
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2010	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																						V		
S	2010	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
S	2010	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																								
S	2010	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
S	2010	Aveo	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																								
S	2010	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module					V																																																	V		V
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2010	Aveo	Chassis	Electronic Brake Control Module													V																																										
S	2010	Aveo	Chassis	Tire Pressure Monitor																																																								
S	2010	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2010	Aveo	Body	Remote Function Actuation																																									V															
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
S	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																								
S	2010	Sail	Powertrain	Transmission Control Module																																																						V		
S	2010	Sail	Chassis	Electronic Brake Control Module																																																								
S	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2011	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																							V		
S	2011	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
S	2011	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																								
S	2011	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
S	2011	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module					V																																																	V		V
S	2011	Aveo	Powertrain	(G)1.6L L4 LXV Engine Control Module					V																																																	V		V
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2011	Aveo	Chassis	Electronic Brake Control Module													V																																										
S	2011	Aveo	Chassis	Tire Pressure Monitor																																																								
S	2011	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2011	Aveo	Body	Remote Function Actuation																																									V															
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																								
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																								
S	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																								
S	2011	Sail	Powertrain	Transmission Control Module																																																						V		
S	2011	Sail	Chassis	Electronic Brake Control Module																																																								
S	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																						V		
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
S	2012	Aveo	Powertrain	Fuel Pump Control Module																																																										
S	2012	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2012	Aveo	Chassis	Electronic Brake Control Module													V																																												
S	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	Aveo	Chassis	Electric Power Steering Control Module																																																										
S	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2012	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2012	Aveo	Body	Body Control Module Hatchback																																																										
S	2012	Aveo	Body	Body Control Module Sedan																																																										
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	Aveo	Body	Passenger Presence Module																																																										
S	2012	Aveo	Body	Instrument Cluster																																																										
S	2012	Aveo	Body	Radio																																																										
S	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
S	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2012	Aveo	Body	Front Seat Heating Control Module																																																										
S	2012	Aveo	Body	Remote Function Actuation																																									V																
S	2012	Aveo	Body	Parking Assist Control Module																																																										
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																											
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																											
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																											
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																											
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
S	2012	Sail	Powertrain	Transmission Control Module																																																					V				
S	2012	Sail	Chassis	Electronic Brake Control Module																																																											
S	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																						V				
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
S	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
S	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																											
S	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
S	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
S	2013	Aveo	Powertrain	Fuel Injector Control Module																																																											
S	2013	Aveo	Powertrain	Fuel Pump Control Module																																																											
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2013	Aveo	Chassis	Electronic Brake Control Module													V																																														
S	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2013	Aveo	Chassis	Electric Power Steering Control Module																																																											
S	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2013	Aveo	Body	Body Control Module Hatchback																																																											
S	2013	Aveo	Body	Body Control Module Sedan																																																											
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2013	Aveo	Body	Passenger Presence Module																																																											
S	2013	Aveo	Body	Instrument Cluster																																																											
S	2013	Aveo	Body	Radio																																																											
S	2013	Aveo	Body	Telematics Communication Interface Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
S	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
S	2013	Aveo	Body	Front Seat Heating Control Module																																																											
S	2013	Aveo	Body	Remote Function Actuation																																								V																		
S	2013	Aveo	Body	Parking Assist Control Module																																																											
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
S	2013	Sail	Powertrain	Transmission Control Module																																																					V					
S	2013	Sail	Chassis	Electronic Brake Control Module																																																											
S	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																											
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																											
S	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																											
S	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																											
S	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																											
S	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
S	2014	Aveo	Powertrain	Chassis Control Module																																																									
S	2014	Aveo	Powertrain	Fuel Injector Control Module																																																									
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2014	Aveo	Chassis	Power Steering Control Module																																																									
S	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2014	Aveo	Body	Body Control Module Hatchback																																																									
S	2014	Aveo	Body	Body Control Module Sedan																																																									
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	Aveo	Body	Instrument Cluster																																																									
S	2014	Aveo	Body	Radio																																																									
S	2014	Aveo	Body	Telematics Communication Interface Control Module																																																									
S	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
S	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
S	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
S	2014	Aveo	Body	Front Seat Heating Control Module																																																									
S	2014	Aveo	Body	Keyless Entry Control Module																																																									
S	2014	Aveo	Body	Parking Assist Control Module																																																									
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																									
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																									
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																									
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																									
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																									
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																									
S	2014	Sail	Powertrain	Transmission Control Module																																																						V		
S	2014	Sail	Chassis	Electronic Brake Control Module																																																									
S	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																									
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
S	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																									
S	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																									
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																									
S	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																									
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																									
S	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																									
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
S	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
S	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
S	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
S	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
S	2015	Aveo	Powertrain	Chassis Control Module																																																													
S	2015	Aveo	Powertrain	Fuel Injector Control Module																																																												
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2015	Aveo	Chassis	Power Steering Control Module																																																												
S	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2015	Aveo	Body	Body Control Module Hatchback																																																												
S	2015	Aveo	Body	Body Control Module Sedan																																																												
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2015	Aveo	Body	Instrument Cluster																																																												
S	2015	Aveo	Body	Radio																																																											
S	2015	Aveo	Body	Telematics Communication Interface Control Module																																																												
S	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
S	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
S	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
S	2015	Aveo	Body	Front Seat Heating Control Module																																																												
S	2015	Aveo	Body	Keyless Entry Control Module																																																												
S	2015	Aveo	Body	Parking Assist Control Module																																																												
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																												
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																												
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																												
S	2015	Sail	Powertrain	Transmission Control Module																																																							V				
S	2015	Sail	Chassis	Electronic Brake Control Module																																																												
S	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
S	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
S	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
S	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
S	2016	Aveo	Powertrain	Chassis Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Power Steering Control Module																																																										
S	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	Aveo	Body	Body Control Module Hatchback																																																										
S	2016	Aveo	Body	Body Control Module Sedan																																																										
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Body	Instrument Cluster																																																										
S	2016	Aveo	Body	Radio																																																										
S	2016	Aveo	Body	Telematics Communication Interface Control Module																																																										
S	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2016	Aveo	Body	Front Seat Heating Control Module																																																										
S	2016	Aveo	Body	Parking Assist Control Module																																																										
S	2016	Aveo	Body	Keyless Entry Control Module																																																										
S	2016	Aveo	Body	Frontview Camera Module																																																										
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																										
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2016	Sail	Powertrain	Transmission Control Module																																																					V			
S	2016	Sail	Chassis	Electronic Brake Control Module																																																									
S	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2004	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																							V															V	
T	2004	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
T	2004	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																									
T	2004	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
T	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
T	2004	ALL	Powertrain	Transmission Control Module																																																									
T	2004	ALL	Chassis	Electronic Brake Control Module													V																																											
T	2004	ALL	Chassis	Electronic Brake Control Module													V																																											
T	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2004	ALL	Body	Remote Function Actuation																																								V															
T	2005	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																							V															V	
T	2005	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
T	2005	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																									
T	2005	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
T	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
T	2005	ALL	Powertrain	Transmission Control Module																																																									
T	2005	ALL	Chassis	Electronic Brake Control Module													V																																											
T	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2005	ALL	Body	Remote Function Actuation																																								V															
T	2006	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								V	
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																									
T	2006	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																									
T	2006	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module			V																																																					
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																									
T	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2006	ALL	Chassis	Electronic Brake Control Module													V																																											
T	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2006	ALL	Body	Remote Function Actuation																																								V															
T	2007	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								V	
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																									
T	2007	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																									
T	2007	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module			V																																																					
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																									
T	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																									
T	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2007	ALL	Chassis	Electronic Brake Control Module													V																																											
T	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2007	ALL	Body	Remote Function Actuation																																								V															
T	2008	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																							V	
T	2008	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																							V	
T	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2008	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module			V																																																							
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
T	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module			V																																																							
T	2008	ALL	Powertrain	Transmission Control Module																																																										
T	2008	ALL	Powertrain	Transmission Control Module																																																										
T	2008	ALL	Chassis	Electronic Brake Control Module													V																																													
T	2008	ALL	Chassis	Tire Pressure Monitor																																																										
T	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2008	ALL	Body	Remote Function Actuation																																								V																	
T	2008	ALL	Body	Passenger Presence System																																																									
T	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
T	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
T	2009	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module					V																																																V		V
T	2009	ALL	Powertrain	Transmission Control Module																																																									
T	2009	ALL	Powertrain	Transmission Control Module																																																										
T	2009	ALL	Chassis	Electronic Brake Control Module													V																																													
T	2009	ALL	Chassis	Tire Pressure Monitor																																																										
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2009	ALL	Body	Supplemental Inflatable Restraint																			V																																							
T	2009	ALL	Body	Instrument Panel Cluster																																																										
T	2009	ALL	Body	Passenger Presence System																																																										
T	2009	ALL	Body	Theft Deterrent Module		V																																																								
T	2009	ALL	Body	Radio																																																										
T	2009	ALL	Body	Remote Function Actuation																																								V																	
T	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
T	2010	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2010	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module					V																																															V		V
T	2010	ALL	Powertrain	Transmission Control Module																																																										
T	2010	ALL	Powertrain	Transmission Control Module																																																										
T	2010	ALL	Chassis	Electronic Brake Control Module													V																																													
T	2010	ALL	Chassis	Tire Pressure Monitor																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																			V																																							
T	2010	ALL	Body	Instrument Panel Cluster																																																										
T	2010	ALL	Body	Passenger Presence System																																																										
T	2010	ALL	Body	Theft Deterrent Module		V																																																								
T	2010	ALL	Body	Radio																																																										
T	2010	ALL	Body	Remote Function Actuation																																								V																	
T	2011	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																							V		
T	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2011	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2011	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module Argentia			V																																																							
T	2011	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module					V																																															V		V
T	2011	ALL	Powertrain	(G)1.6L L4 LXV Engine Control Module					V																																															V		V
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2011	ALL	Chassis	Electronic Brake Control Module													V																																													
T	2011	ALL	Chassis	Tire Pressure Monitor																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2011	ALL	Body	Supplemental Inflatable Restraint																			V																																						
T	2011	ALL	Body	Instrument Panel Cluster																																																									
T	2011	ALL	Body	Passenger Presence System																																																									
T	2011	ALL	Body	Theft Deterrent Module		V																																																							
T	2011	ALL	Body	Radio																																																									
T	2011	ALL	Body	Remote Function Actuation																																								V																	
T	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																							V		
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
T	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
T	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																									
T	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
T	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																									
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
T	2012	Aveo	Powertrain	Fuel Injector Control Module																																																									
T	2012	Aveo	Powertrain	Fuel Pump Control Module																																																									
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2012	Aveo	Chassis	Electronic Brake Control Module													V																																												
T	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2012	Aveo	Chassis	Electric Power Steering Control Module																																																									
T	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2012	Aveo	Chassis	Tire Pressure Monitor																																																									
T	2012	Aveo	Body	Body Control Module Hatchback																																																									
T	2012	Aveo	Body	Body Control Module Sedan																																																									
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2012	Aveo	Body	Passenger Presence Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2012	Aveo	Body	Instrument Cluster																																																										
T	2012	Aveo	Body	Radio																																																										
T	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
T	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2012	Aveo	Body	Front Seat Heating Control Module																																																										
T	2012	Aveo	Body	Remote Function Actuation																																								V																	
T	2012	Aveo	Body	Parking Assist Control Module																																																										
T	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																									V	
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
T	2013	Aveo	Powertrain	Fuel Injector Control Module																																																										
T	2013	Aveo	Powertrain	Fuel Pump Control Module																																																										
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2013	Aveo	Chassis	Electronic Brake Control Module													V																																												
T	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	Aveo	Chassis	Electric Power Steering Control Module																																																										
T	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2013	Aveo	Body	Body Control Module Hatchback																																																										
T	2013	Aveo	Body	Body Control Module Sedan																																																										
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	Aveo	Body	Passenger Presence Module																																																										
T	2013	Aveo	Body	Instrument Cluster																																																										
T	2013	Aveo	Body	Radio																																																										
T	2013	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2013	Aveo	Body	Front Seat Heating Control Module																																																										
T	2013	Aveo	Body	Remote Function Actuation																																										V																
T	2013	Aveo	Body	Parking Assist Control Module																																																									
T	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																									
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																									
T	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																									
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																									
T	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
T	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																									
T	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																									
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
T	2014	Aveo	Powertrain	Chassis Control Module																																																									
T	2014	Aveo	Powertrain	Fuel Injector Control Module																																																									
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2014	Aveo	Chassis	Power Steering Control Module																																																									
T	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2014	Aveo	Body	Body Control Module Hatchback																																																									
T	2014	Aveo	Body	Body Control Module Sedan																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Aveo	Body	Instrument Cluster																																																										
T	2014	Aveo	Body	Radio																																																										
T	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2014	Aveo	Body	Front Seat Heating Control Module																																																										
T	2014	Aveo	Body	Keyless Entry Control Module																																																										
T	2014	Aveo	Body	Parking Assist Control Module																																																										
T	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
T	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
T	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
T	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
T	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
T	2015	Aveo	Powertrain	Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2015	Aveo	Powertrain	Fuel Injector Control Module																																																								
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2015	Aveo	Chassis	Power Steering Control Module																																																									
T	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2015	Aveo	Body	Body Control Module Hatchback																																																									
T	2015	Aveo	Body	Body Control Module Sedan																																																									
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Aveo	Body	Instrument Cluster																																																									
T	2015	Aveo	Body	Radio																																																									
T	2015	Aveo	Body	Telematics Communication Interface Control Module																																																									
T	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
T	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
T	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
T	2015	Aveo	Body	Front Seat Heating Control Module																																																									
T	2015	Aveo	Body	Keyless Entry Control Module																																																									
T	2015	Aveo	Body	Parking Assist Control Module																																																									
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																									
T	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																									
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																									
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
T	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																									
T	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																									
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																									
T	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																									
T	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
T	2016	Aveo	Powertrain	Chassis Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2016	Aveo	Chassis	Power Steering Control Module																																																										
T	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2016	Aveo	Body	Body Control Module Hatchback																																																										
T	2016	Aveo	Body	Body Control Module Sedan																																																										
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Aveo	Body	Instrument Cluster																																																										
T	2016	Aveo	Body	Radio																																																										
T	2016	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2016	Aveo	Body	Front Seat Heating Control Module																																																										
T	2016	Aveo	Body	Parking Assist Control Module																																																										
T	2016	Aveo	Body	Keyless Entry Control Module																																																										
T	2016	Aveo	Body	Frontview Camera Module																																																										
U	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																							V																	V	
U	2004	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																							V																	V	
U	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
U	2004	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
U	2004	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
U	2004	ALL	Chassis	Electronic Brake Control Module													V																																												
U	2004	ALL	Chassis	Electronic Brake Control Module													V																																												
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2004	ALL	Body	Remote Function Actuation																																									V																
U	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
U	2005	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																										
U	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
U	2005	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
U	2005	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
U	2005	ALL	Chassis	Electronic Brake Control Module													V																																												
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2005	ALL	Body	Remote Function Actuation																																									V																
U	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									V	
U	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
U	2006	ALL	Powertrain	Transmission Control Module																																																										
U	2006	ALL	Chassis	Electronic Brake Control Module													V																																												
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2006	ALL	Body	Remote Function Actuation																																									V																
U	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									V	
U	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
U	2007	ALL	Powertrain	Transmission Control Module																																																										
U	2007	ALL	Chassis	Electronic Brake Control Module													V																																												
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
U	2007	ALL	Body	Remote Function Actuation																																									V															
U	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																						V	
U	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																						V	
U	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																							
U	2008	ALL	Powertrain	Transmission Control Module																																																							
U	2008	ALL	Chassis	Electronic Brake Control Module													V																																										
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																							
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																							
U	2008	ALL	Body	Remote Function Actuation																																									V															
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																							
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																							
U	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																							
U	2010	Sail	Powertrain	Transmission Control Module																																																					V		
U	2010	Sail	Chassis	Electronic Brake Control Module																																																							
U	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																							
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																							
U	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																							
U	2011	Sail	Powertrain	Transmission Control Module																																																					V		
U	2011	Sail	Chassis	Electronic Brake Control Module																																																							
U	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																							
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																							
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																							
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																							
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																							
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																							
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																							
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																							
U	2012	Sail	Powertrain	Transmission Control Module																																																					V		
U	2012	Sail	Chassis	Electronic Brake Control Module																																																							
U	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																							
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																							
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																							
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																							
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																							
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																							
U	2013	Sail	Powertrain	Transmission Control Module																																																					V		
U	2013	Sail	Chassis	Electronic Brake Control Module																																																							
U	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																							
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																							
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																							
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																							
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																							
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																							
U	2014	Sail	Powertrain	Transmission Control Module																																																					V		
U	2014	Sail	Chassis	Electronic Brake Control Module																																																							
U	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
U	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																											
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
U	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																											
U	2015	Sail	Powertrain	Transmission Control Module																																																					V				
U	2015	Sail	Chassis	Electronic Brake Control Module																																																											
U	2015	Sail	Chassis	Electronic Brake Control Module																																																											
U	2015	Sail	Chassis	Power Steering Control Module																																																											
U	2015	Sail	Body	Body Control Module																																																											
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2015	Sail	Body	Radio/HVAC Control																																																											
U	2015	Sail	Body	HVAC Control Module																																																											
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
U	2016	Sail	Powertrain	1.2L LMU Transmission Control Module																																																					V				
U	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																											
U	2016	Sail	Powertrain	1.3L LDV Transmission Control Module																																																					V				
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
U	2016	Sail	Powertrain	1.4L LCU Transmission Control Module																																																					V				
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																											
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																											
U	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																											
U	2016	Sail	Chassis	Electronic Brake Control Module																																																											
U	2016	Sail	Chassis	Electronic Brake Control Module																																																											
U	2016	Sail	Chassis	Power Steering Control Module																																																											
U	2016	Sail	Body	Body Control Module																																																											
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2016	Sail	Body	Radio/HVAC Control																																																											
U	2016	Sail	Body	Radio																																																											
U	2016	Sail	Body	HVAC Control Module																																																											
V	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
V	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								V			
V	2004	ALL	Powertrain	Transmission Control Module 4 Speed																																																											
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes											V	V	V																																														
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control No													V																																														
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2004	ALL	Body	ISU																																								V				V													
V	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
V	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								V			
V	2005	ALL	Powertrain	Transmission Control Module 4 Speed																																																											
V	2005	ALL	Chassis	Electronic Brake Control Module													V																																														
V	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2005	ALL	Body	ISU																																								V				V													
V	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
V	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								V			

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
V	2006	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes													V																																													
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control No													V																																													
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2006	ALL	Body	ISU																																								V				V													
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																								V		
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector Control Module																																																										
V	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
V	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module			V																																																								
V	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																								V		
V	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																							V		
V	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																											
V	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
V	2007	ALL	Chassis	Electronic Brake Control Module													V																																														
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2007	ALL	Body	ISU																																								V				V													
V	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module			V																																																					V		
V	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module			V																																																					V		
V	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
V	2008	ALL	Chassis	Electronic Brake Control Module													V																																														
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2008	ALL	Body	ISU																																								V				V													
V	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module			V																																																					V		
V	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module			V																																																					V		
V	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
V	2009	ALL	Chassis	Electronic Brake Control Module													V																																														
V	2009	ALL	Body	ISU																																								V				V													
V	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module			V																																																								
V	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module			V																																																					V		
V	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module			V																																																					V		
V	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
V	2010	ALL	Chassis	Electronic Brake Control Module													V																																														
V	2010	ALL	Body	ISU																																								V				V													
V	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module			V																																																								
V	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module			V																																																						V		
V	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module			V																																																					V		
V	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
V	2011	ALL	Chassis	Electronic Brake Control Module													V																																														
V	2011	ALL	Body	ISU																																								V				V													
W	2004	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module					V																																																						
W	2004	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module					V																																																						
W	2004	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module					V																																																						
W	2004	ALL	Powertrain	Transmission Control Module																																																											
W	2004	ALL	Body	Body Control Module					V												V																																										
W	2004	ALL	Body	Digital Radio Receiver																																																											
W	2004	ALL	Body	Driver Information Center																																																										
W	2004	ALL	Body	Heating and Air Conditioning																																																											
W	2004	ALL	Body	Instrument Panel Cluster																																																											
W	2004	ALL	Body	Personalization																																																											
W	2004	ALL	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
W	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module					V																																																					
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module					V																																																					
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module					V																																																					
W	2005	ALL	Powertrain	Transmission Control Module																																																										
W	2005	ALL	Body	Body Control Module					V												V																																									
W	2005	ALL	Body	Digital Radio Receiver																																																										
W	2005	ALL	Body	Driver Information Center																																																										
W	2005	ALL	Body	Heating and Air Conditioning																																																										
W	2005	ALL	Body	Instrument Panel Cluster																																																										
W	2005	ALL	Body	Personalization																																																										
W	2005	ALL	Body	Radio																																																										
W	2005	ALL	Body	Supplemental Inflatable Restraint																	V																																									
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module					V																																																					
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module					V																																																					
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module					V																																																					
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module			V		V																																																					
W	2006	ALL	Powertrain	Transmission Control Module																																																										
W	2006	ALL	Chassis	Anti-lock Brake System											V	V	V																																													
W	2006	ALL	Body	Digital Radio Receiver																																																										
W	2006	ALL	Body	Radio																																																										
W	2006	ALL	Body	Instrument Panel Cluster																																																										
W	2006	ALL	Body	Seat																																																										
W	2006	ALL	Body	Theft Deterrent Module		V																																																								
W	2006	ALL	Body	Body Control Module			V																													V																											
W	2006	ALL	Body	HVAC C67 Single																																																										
W	2006	ALL	Body	HVAC CJ3 Dual																																																										
W	2006	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2006	ALL	Body	Supplemental Inflatable Restraint																			V																																							
W	2006	ALL	Body	Passenger Presence System																																																										
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module					V																																															V			V
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module					V																																															V			V
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module					V																																															V	V		V
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module					V																																															V			V
W	2007	ALL	Powertrain	Transmission Control Module																																																										
W	2007	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
W	2007	ALL	Body	Body Control Module			V																													V			V																							
W	2007	ALL	Body	Digital Radio Receiver																																																										
W	2007	ALL	Body	Heated Seat Module																																																										
W	2007	ALL	Body	HVAC C67 Single																																																										
W	2007	ALL	Body	HVAC CJ3 Dual																																																										
W	2007	ALL	Body	Instrument Panel Cluster																																																										
W	2007	ALL	Body	Passenger Presence System																																																										
W	2007	ALL	Body	Radio																																																										
W	2007	ALL	Body	Supplemental Inflatable Restraint																			V																																							
W	2007	ALL	Body	Theft Deterrent Module		V																																																								
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module					V																																															V			V
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module					V																																															V			V
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module					V																																															V			V
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module			V		V																																																				
W	2008	ALL	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
W	2008	ALL	Chassis	Electronic Brake Control Module											V	V	V																																											
W	2008	ALL	Body	Body Control Module			V																													V			V																					
W	2008	ALL	Body	Digital Radio Receiver																																																								
W	2008	ALL	Body	Heated Seat Module																																																							
W	2008	ALL	Body	HVAC C67 Single																																																							
W	2008	ALL	Body	HVAC CJ3 Dual																																																							
W	2008	ALL	Body	Instrument Panel Cluster																																																							
W	2008	ALL	Body	Passenger Presence System																																																							
W	2008	ALL	Body	Radio																																																							
W	2008	ALL	Body	Remote Control Door Lock Receiver																																																							
W	2008	ALL	Body	Supplemental Inflatable Restraint																			V																																					
W	2008	ALL	Body	Theft Deterrent Module		V																																																						
W	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module					V																																													V			V
W	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module					V																																													V			V
W	2009	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module					V																																													V			V
W	2009	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module			V		V																																																	
W	2009	ALL	Powertrain	Transmission Control Module																																																							
W	2009	ALL	Chassis	Electronic Brake Control Module											V	V	V																																										
W	2009	ALL	Body	Body Control Module			V																													V			V																					
W	2009	ALL	Body	Digital Radio Receiver																																																							
W	2009	ALL	Body	Heated Seat Module																																																							
W	2009	ALL	Body	HVAC C67 Single																																																							
W	2009	ALL	Body	HVAC CJ3 Dual																																																							
W	2009	ALL	Body	Instrument Panel Cluster																																																							
W	2009	ALL	Body	Passenger Presence System																																																							
W	2009	ALL	Body	Radio																																																							
W	2009	ALL	Body	Remote Control Door Lock Receiver																																																							
W	2009	ALL	Body	Supplemental Inflatable Restraint																			V																																					
W	2009	ALL	Body	Theft Deterrent Module		V																																																					
W	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module					V																																													V			V
W	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module					V																																													V			V
W	2010	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module					V																																													V			V
W	2010	ALL	Powertrain	Transmission Control Module																																																						
W	2010	ALL	Chassis	Electronic Brake Control Module											V	V	V																																										
W	2010	ALL	Body	Body Control Module			V																													V			V																					
W	2010	ALL	Body	Digital Radio Receiver																																																							
W	2010	ALL	Body	Heated Seat Module																																																							
W	2010	ALL	Body	HVAC C67 Single																																																							
W	2010	ALL	Body	HVAC CJ3 Dual																																																							
W	2010	ALL	Body	Instrument Panel Cluster																																																							
W	2010	ALL	Body	Passenger Presence System																																																							
W	2010	ALL	Body	Radio																																																							
W	2010	ALL	Body	Remote Control Door Lock Receiver																																																							
W	2010	ALL	Body	Supplemental Inflatable Restraint																			V																																					
W	2010	ALL	Body	Theft Deterrent Module		V																																																					
W	2011	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module					V																																													V			V
W	2011	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module					V																																													V			V
W	2011	ALL	Powertrain	Transmission Control Module																																																						
W	2011	ALL	Chassis	Electronic Brake Control Module											V	V	V																																										
W	2011	ALL	Body	Body Control Module			V																													V			V																					
W	2011	ALL	Body	Digital Radio Receiver																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
W	2011	ALL	Body	Heated Seat Module																																																										
W	2011	ALL	Body	HVAC C67 Single																																																										
W	2011	ALL	Body	HVAC CJ3 Dual																																																										
W	2011	ALL	Body	Instrument Panel Cluster																																																										
W	2011	ALL	Body	Passenger Presence System																																																										
W	2011	ALL	Body	Radio																																																										
W	2011	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2011	ALL	Body	Supplemental Inflatable Restraint																			V																																							
W	2011	ALL	Body	Theft Deterrent Module		V																																																								
W	2012	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module					V																																																					
W	2012	ALL	Powertrain	Transmission Control Module																																																										
W	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
W	2012	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
W	2012	ALL	Body	Body Control Module			V																													V			V																							
W	2012	ALL	Body	Digital Radio Receiver																																																										
W	2012	ALL	Body	Heated Seat Module																																																										
W	2012	ALL	Body	HVAC C67 Single																																																										
W	2012	ALL	Body	HVAC CJ3 Dual																																																										
W	2012	ALL	Body	Instrument Panel Cluster																																																										
W	2012	ALL	Body	Passenger Presence System																																																										
W	2012	ALL	Body	Radio																																																										
W	2012	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2012	ALL	Body	Theft Deterrent Module		V																																																								
W	2013	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module					V																																																					V
W	2013	ALL	Powertrain	Transmission Control Module																																																										
W	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
W	2013	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
W	2013	ALL	Body	Body Control Module			V																													V			V																							
W	2013	ALL	Body	Digital Radio Receiver																																																										
W	2013	ALL	Body	Heated Seat Module																																																										
W	2013	ALL	Body	HVAC C67 Single																																																										
W	2013	ALL	Body	HVAC CJ3 Dual																																																										
W	2013	ALL	Body	Instrument Panel Cluster																																																										
W	2013	ALL	Body	Passenger Presence System																																																										
W	2013	ALL	Body	Radio																																																										
W	2013	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2013	ALL	Body	Theft Deterrent Module		V																																																								
W	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
W	2014	Impala	Chassis	Electronic Brake Control Module																																																										
W	2014	Impala	Body	Body Control Module																																																										
W	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2014	Impala	Body	Passenger Presence Module																																																										
W	2014	Impala	Body	Instrument Cluster																																																										
W	2014	Impala	Body	Radio																																																										
W	2014	Impala	Body	Digital Radio Receiver Control Module																																																										
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																										
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
W	2014	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
W	2014	Impala	Body	HVAC Manual Control Single Zone (C67)																																																										
W	2014	Impala	Body	Front Seat Heating Control Module																																																										
W	2014	Impala	Body	Remote Control Door Lock Receiver																																																										
W	2014	Impala	Body	Theft Deterrent Module		V																																																								
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
W	2014	Lumina	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
W	2014	Lumina	Powertrain	Fuel Injector Control Module																																																										
W	2014	Lumina	Powertrain	Chassis Control Module																																																										
W	2014	Lumina	Chassis	Electronic Brake Control Module																																																										
W	2014	Lumina	Chassis	Parking Brake Control Module																																																										
W	2014	Lumina	Chassis	Power Steering Control Module																																																										
W	2014	Lumina	Chassis	Steering Wheel Angle Sensor Module																																																										
W	2014	Lumina	Chassis	Suspension Control Module																																																										
W	2014	Lumina	Body	Body Control Module Coupe																																																										
W	2014	Lumina	Body	Body Control Module Sedan																																																										
W	2014	Lumina	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2014	Lumina	Body	Instrument Cluster																																																										
W	2014	Lumina	Body	Head-Up Display Module																																																										
W	2014	Lumina	Body	Radio Control																																																										
W	2014	Lumina	Body	HVAC Control																																																										
W	2014	Lumina	Body	Headlamp Control Module																																																										
W	2014	Lumina	Body	Trailer Interface Control Module																																																										
W	2014	Lumina	Body	Radio																																																										
W	2014	Lumina	Body	HVAC Control Module																																																										
W	2014	Lumina	Body	Keyless Entry Control Module																																																										
W	2014	Lumina	Body	Right Side Object Detection Control Module																																																										
W	2014	Lumina	Body	Left Side Object Detection Control Module																																																										
W	2014	Lumina	Body	Parking Assist Control Module																																																										
W	2014	Lumina	Body	Frontview Camera Module																																																										
W	2014	Lumina	Body	Steering Column Lock Control Module																																																										
W	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
W	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
W	2015	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
W	2015	Impala	Chassis	Electronic Brake Control Module																																																										
W	2015	Impala	Body	Body Control Module																																																										
W	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2015	Impala	Body	Passenger Presence Module																																																										
W	2015	Impala	Body	Instrument Cluster																																																										
W	2015	Impala	Body	Radio																																																										
W	2015	Impala	Body	Digital Radio Receiver Control Module																																																										
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 9																																																										
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 10																																																										
W	2015	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
W	2015	Impala	Body	HVAC Manual Control Single Zone (C67)																																																										
W	2015	Impala	Body	Front Seat Heating Control Module																																																										
W	2015	Impala	Body	Remote Control Door Lock Receiver																																																										
W	2015	Impala	Body	Theft Deterrent Module		V																																																								
W	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
W	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
W	2016	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
W	2016	Impala	Chassis	Electronic Brake Control Module																																																										
W	2016	Impala	Body	Body Control Module																																																										
W	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2016	Impala	Body	Passenger Presence Module																																																										
W	2016	Impala	Body	Instrument Cluster																																																										
W	2016	Impala	Body	Radio																																																										
W	2016	Impala	Body	Digital Radio Receiver Control Module																																																										
W	2016	Impala	Body	Telematics Communication Interface Control Module																																																										
W	2016	Impala	Body	HVAC Manual Control Dual Zone (CJ2)																																																										
W	2016	Impala	Body	HVAC Manual Control Single Zone (C67)																																																										
W	2016	Impala	Body	Front Seat Heating Control Module																																																										
W	2016	Impala	Body	Remote Control Door Lock Receiver																																																										
W	2016	Impala	Body	Theft Deterrent Module		V																																																								
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Auto			V	V	V																																																					
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Manual			V	V	V																																																					
Y	2004	ALL	Powertrain	(S)5.7L V8 LS6 Engine Control Module			V	V	V																																																					
Y	2004	ALL	Powertrain	Transmission Control Module																																																										
Y	2004	ALL	Chassis	RTD																																																										
Y	2004	ALL	Body	Body Control Module																																																										
Y	2004	ALL	Body	Heating and Air Conditioning																																																										
Y	2004	ALL	Body	Instrument Panel Cluster																																																										
Y	2004	ALL	Body	Left Door Control Module																																																										
Y	2004	ALL	Body	Radio																																																										
Y	2004	ALL	Body	Remote Function Actuation																																											V															
Y	2004	ALL	Body	Right Door Control Module																																																										
Y	2004	ALL	Body	Seat Control Module																																																										
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2005	ALL	Powertrain	Engine Control Module			V		V																																																					
Y	2005	ALL	Powertrain	Transmission Control Module																																																										
Y	2005	ALL	Chassis	Electronic Brake Control Module										V	V	V																																														
Y	2005	ALL	Chassis	Electronic Suspension Control																																																										
Y	2005	ALL	Chassis	Steering Wheel and Column					V																																																					
Y	2005	ALL	Body	Amplifier																																																										
Y	2005	ALL	Body	Body Control Module			V																																V			V																				
Y	2005	ALL	Body	Digital Radio Receiver																																																										
Y	2005	ALL	Body	Driver Door Module																																																										
Y	2005	ALL	Body	Driver Door Switch																																																										
Y	2005	ALL	Body	Driver Position Module																			V	V	V	V																																				
Y	2005	ALL	Body	Folding Top Module																																																										
Y	2005	ALL	Body	Head Up Display																																																										
Y	2005	ALL	Body	HVAC Control Module																			V																																							
Y	2005	ALL	Body	Instrument Panel Cluster																																																										
Y	2005	ALL	Body	Navigation Radio							V	V																																																		
Y	2005	ALL	Body	Passenger Door Module																																																										
Y	2005	ALL	Body	Radio								V																																																		
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																											V															
Y	2005	ALL	Body	Supplemental Inflatable Restraint	V																																																									
Y	2006	ALL	Powertrain	Engine Control Module			V		V																																																					
Y	2006	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2006	ALL	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Y	2006	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
Y	2006	ALL	Chassis	Electronic Suspension Control																																																										
Y	2006	ALL	Chassis	Steering Wheel and Column																																																										
Y	2006	ALL	Body	Body Control Module			V																																V				V																		
Y	2006	ALL	Body	CD Changer																																																									
Y	2006	ALL	Body	Digital Radio Receiver																																																										
Y	2006	ALL	Body	Driver Door Module																																																										
Y	2006	ALL	Body	Driver Door Switch																																																										
Y	2006	ALL	Body	Driver Position Module																			V	V	V	V																																				
Y	2006	ALL	Body	Folding Top Module																																																										
Y	2006	ALL	Body	Head Up Display																																																										
Y	2006	ALL	Body	HVAC Control Module																			V																																								
Y	2006	ALL	Body	Instrument Panel Cluster																																																											
Y	2006	ALL	Body	Navigation Radio							V	V																																																		
Y	2006	ALL	Body	Passenger Door Module																																																										
Y	2006	ALL	Body	Radio								V																																																	
Y	2006	ALL	Body	Remote Control Door Lock Receiver																																											V															
Y	2006	ALL	Body	Supplemental Inflatable Restraint	V																																																									
Y	2007	ALL	Powertrain	Engine Control Module			V		V																																																					
Y	2007	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	ALL	Powertrain	Transmission Control Module																																																										
Y	2007	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
Y	2007	ALL	Chassis	Electronic Suspension Control																																																										
Y	2007	ALL	Body	Body Control Module			V																																V				V																		
Y	2007	ALL	Body	CD Changer																																																										
Y	2007	ALL	Body	Digital Radio Receiver																																																										
Y	2007	ALL	Body	Driver Door Module																																																										
Y	2007	ALL	Body	Driver Door Switch																																																										
Y	2007	ALL	Body	Driver Position Module																			V	V	V	V																																				
Y	2007	ALL	Body	Folding Top Module																																																										
Y	2007	ALL	Body	Head Up Display																																																										
Y	2007	ALL	Body	HVAC Control Module																			V																																								
Y	2007	ALL	Body	Instrument Panel Cluster																																																											
Y	2007	ALL	Body	Navigation Radio							V	V																																																		
Y	2007	ALL	Body	Passenger Door Module																																																										
Y	2007	ALL	Body	Radio																																																										
Y	2007	ALL	Body	Remote Control Door Lock Receiver																																											V															
Y	2007	ALL	Body	Steering Column Lock Module																																																											
Y	2007	ALL	Body	Supplemental Inflatable Restraint	V																																																										
Y	2008	ALL	Powertrain	Engine Control Module					V																																																	V		V
Y	2008	ALL	Powertrain	Exhaust Flow Control Module																																																											
Y	2008	ALL	Powertrain	Transmission Control Module																																																											
Y	2008	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
Y	2008	ALL	Chassis	Electronic Suspension Control																																																											
Y	2008	ALL	Body	Body Control Module			V																																V				V																		
Y	2008	ALL	Body	CD Changer																																																										
Y	2008	ALL	Body	Digital Radio Receiver																																																											
Y	2008	ALL	Body	Driver Door Module																																																											
Y	2008	ALL	Body	Driver Door Switch																																																											
Y	2008	ALL	Body	Driver Position Module																			V	V	V	V																																				
Y	2008	ALL	Body	Folding Top Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Y	2008	ALL	Body	Head Up Display																																																								
Y	2008	ALL	Body	HVAC Control Module																			V																																					
Y	2008	ALL	Body	Instrument Panel Cluster																																																								
Y	2008	ALL	Body	Navigation Radio							V	V																																																
Y	2008	ALL	Body	Passenger Door Module																																																								
Y	2008	ALL	Body	Radio								V																																																
Y	2008	ALL	Body	Personal Audio Link Module																																																								
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																											V													
Y	2008	ALL	Body	Steering Column Lock Module																																																								
Y	2008	ALL	Body	Supplemental Inflatable Restraint	V																																																								
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module					V																																															V	V		V
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																								
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																								
Y	2009	ALL	Chassis	Electronic Brake Control Module											V	V	V																																											
Y	2009	ALL	Chassis	Electronic Suspension Control																																																									
Y	2009	ALL	Body	Body Control Module			V																																V				V																	
Y	2009	ALL	Body	CD Changer																																																								
Y	2009	ALL	Body	Digital Radio Receiver																																																								
Y	2009	ALL	Body	Driver Door Module																																																								
Y	2009	ALL	Body	Driver Door Switch																																																								
Y	2009	ALL	Body	Driver Position Module																			V	V	V	V																																		
Y	2009	ALL	Body	Folding Top Module																																																								
Y	2009	ALL	Body	Head Up Display																																																								
Y	2009	ALL	Body	HVAC Control Module																			V																																						
Y	2009	ALL	Body	Instrument Panel Cluster																																																								
Y	2009	ALL	Body	Navigation Radio							V	V																																																
Y	2009	ALL	Body	Passenger Door Module																																																								
Y	2009	ALL	Body	Radio								V																																															
Y	2009	ALL	Body	Personal Audio Link Module																																																								
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																											V													
Y	2009	ALL	Body	Steering Column Lock Module																																																								
Y	2009	ALL	Body	Supplemental Inflatable Restraint	V																																																								
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module					V																																														V			V
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																								
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																								
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module					V																																														V	V		
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																								
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																								
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module					V																																														V	V		
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																								
Y	2010	ALL	Chassis	Electronic Brake Control Module											V	V	V																																											
Y	2010	ALL	Chassis	Electronic Suspension Control																																																									
Y	2010	ALL	Body	Body Control Module			V																																V				V																	
Y	2010	ALL	Body	CD Changer																																																								
Y	2010	ALL	Body	Digital Radio Receiver																																																								
Y	2010	ALL	Body	Driver Door Module																																																								
Y	2010	ALL	Body	Driver Door Switch																																																								
Y	2010	ALL	Body	Driver Position Module																			V	V	V	V																																		
Y	2010	ALL	Body	Folding Top Module																																																								
Y	2010	ALL	Body	Head Up Display																																																								
Y	2010	ALL	Body	HVAC Control Module																			V																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Y	2010	ALL	Body	Instrument Panel Cluster																																																										
Y	2010	ALL	Body	Navigation Radio							V	V																																																		
Y	2010	ALL	Body	Passenger Door Module																																																										
Y	2010	ALL	Body	Radio								V																																																		
Y	2010	ALL	Body	Personal Audio Link Module																																																										
Y	2010	ALL	Body	Remote Control Door Lock Receiver																																											V															
Y	2010	ALL	Body	Steering Column Lock Module																																																										
Y	2010	ALL	Body	Supplemental Inflatable Restraint	V																																																									
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module					V																																															V			V
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																										
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module					V																																															V	V					
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module					V																																															V	V					
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2011	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
Y	2011	ALL	Chassis	Electronic Suspension Control																																																										
Y	2011	ALL	Body	Body Control Module			V																																V			V																				
Y	2011	ALL	Body	CD Changer																																																										
Y	2011	ALL	Body	Digital Radio Receiver																																																										
Y	2011	ALL	Body	Driver Door Module																																																										
Y	2011	ALL	Body	Driver Door Switch																																																										
Y	2011	ALL	Body	Driver Position Module																			V	V	V	V																																				
Y	2011	ALL	Body	Folding Top Module																																																										
Y	2011	ALL	Body	Head Up Display																																																										
Y	2011	ALL	Body	HVAC Control Module																			V																																							
Y	2011	ALL	Body	Instrument Panel Cluster																																																										
Y	2011	ALL	Body	Navigation Radio							V	V																																																		
Y	2011	ALL	Body	Passenger Door Module																																																										
Y	2011	ALL	Body	Radio								V																																																		
Y	2011	ALL	Body	Personal Audio Link Module																																																										
Y	2011	ALL	Body	Remote Control Door Lock Receiver																																											V															
Y	2011	ALL	Body	Steering Column Lock Module																																																										
Y	2011	ALL	Body	Supplemental Inflatable Restraint	V																																																									
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module					V																																															V			V			
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																										
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module					V																																															V	V					
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module					V																																															V	V					
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2012	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
Y	2012	ALL	Chassis	Electronic Suspension Control																																																										
Y	2012	ALL	Body	Body Control Module			V																																V			V																				
Y	2012	ALL	Body	CD Changer																																																										
Y	2012	ALL	Body	Digital Radio Receiver																																																										
Y	2012	ALL	Body	Driver Door Module																																																										
Y	2012	ALL	Body	Driver Door Switch																																																										
Y	2012	ALL	Body	Driver Position Module																			V	V	V	V																																				

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Y	2012	ALL	Body	Folding Top Module																																																									
Y	2012	ALL	Body	Head Up Display																																																									
Y	2012	ALL	Body	HVAC Control Module																			V																																						
Y	2012	ALL	Body	Instrument Panel Cluster																																																									
Y	2012	ALL	Body	Navigation Radio							V	V																																																	
Y	2012	ALL	Body	Passenger Door Module																																																									
Y	2012	ALL	Body	Radio								V																																																
Y	2012	ALL	Body	Personal Audio Link Module																																																									
Y	2012	ALL	Body	Remote Control Door Lock Receiver																																											V														
Y	2012	ALL	Body	Steering Column Lock Module																																																									
Y	2012	ALL	Body	Supplemental Inflatable Restraint	V																																																									
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module					V																																															V			V
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																									
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																									
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module					V																																															V	V			
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																									
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																									
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module					V																																															V	V			
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																									
Y	2013	ALL	Chassis	Electronic Brake Control Module											V	V	V																																												
Y	2013	ALL	Chassis	Electronic Suspension Control																																																										
Y	2013	ALL	Body	Body Control Module			V																																V				V																		
Y	2013	ALL	Body	CD Changer																																																									
Y	2013	ALL	Body	Digital Radio Receiver																																																									
Y	2013	ALL	Body	Driver Door Module																																																									
Y	2013	ALL	Body	Driver Door Switch																																																									
Y	2013	ALL	Body	Driver Position Module																			V	V	V	V																																				
Y	2013	ALL	Body	Folding Top Module																																																										
Y	2013	ALL	Body	Head Up Display																																																									
Y	2013	ALL	Body	HVAC Control Module																			V																																							
Y	2013	ALL	Body	Instrument Panel Cluster																																																										
Y	2013	ALL	Body	Navigation Radio							V	V																																																	
Y	2013	ALL	Body	Passenger Door Module																																																									
Y	2013	ALL	Body	Radio								V																																																
Y	2013	ALL	Body	Personal Audio Link Module																																																									
Y	2013	ALL	Body	Remote Control Door Lock Receiver																																											V														
Y	2013	ALL	Body	Steering Column Lock Module																																																									
Y	2013	ALL	Body	Supplemental Inflatable Restraint	V																																																									
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																									
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																									
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																									
Y	2014	Corvette	Powertrain	Chassis Control Module																																																									
Y	2014	Corvette	Chassis	Electronic Brake Control Module																																																									
Y	2014	Corvette	Chassis	Parking Brake Control Module																																																									
Y	2014	Corvette	Chassis	Power Steering Control Module																																																									
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																									
Y	2014	Corvette	Chassis	Suspension Control Module																																																									
Y	2014	Corvette	Body	Body Control Module Convertible																																																									
Y	2014	Corvette	Body	Body Control Module Coupe																																																									
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
Y	2014	Corvette	Body	Passenger Presence Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Y	2014	Corvette	Body	Instrument Cluster																																																										
Y	2014	Corvette	Body	Radio/HVAC Control																																																										
Y	2014	Corvette	Body	Inside Rearview Mirror																																																										
Y	2014	Corvette	Body	Radio																																																										
Y	2014	Corvette	Body	Amplifier																																																										
Y	2014	Corvette	Body	Human Machine Interface Control Module																																																										
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2014	Corvette	Body	HVAC Control Module																																																										
Y	2014	Corvette	Body	Seat Memory Control Module - Passenger																																																										
Y	2014	Corvette	Body	Seat Memory Control Module - Driver																																																										
Y	2014	Corvette	Body	Folding Top Control Module																																																										
Y	2014	Corvette	Body	Keyless Entry Control Module																																																										
Y	2014	Corvette	Body	Steering Column Lock Control Module																																																										
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																										
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																										
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																										
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Automatic Transmission																																																										
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Manual Transmission																																																										
Y	2015	Corvette	Powertrain	6.2L LT4 Transmission Control Module																																																										
Y	2015	Corvette	Powertrain	Chassis Control Module																																																										
Y	2015	Corvette	Chassis	Electronic Brake Control Module																																																										
Y	2015	Corvette	Chassis	Parking Brake Control Module																																																										
Y	2015	Corvette	Chassis	Power Steering Control Module																																																										
Y	2015	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																										
Y	2015	Corvette	Chassis	Suspension Control Module																																																										
Y	2015	Corvette	Body	Body Control Module Convertible																																																										
Y	2015	Corvette	Body	Body Control Module Coupe																																																										
Y	2015	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Y	2015	Corvette	Body	Passenger Presence Module																																																										
Y	2015	Corvette	Body	Instrument Cluster																																																										
Y	2015	Corvette	Body	Radio/HVAC Control																																																										
Y	2015	Corvette	Body	Vehicle Performance Data Recorder																																																										
Y	2015	Corvette	Body	Inside Rearview Mirror																																																										
Y	2015	Corvette	Body	Radio																																																										
Y	2015	Corvette	Body	Amplifier																																																										
Y	2015	Corvette	Body	Human Machine Interface Control Module																																																										
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2015	Corvette	Body	HVAC Control Module																																																										
Y	2015	Corvette	Body	Seat Memory Control Module - Passenger																																																										
Y	2015	Corvette	Body	Seat Memory Control Module - Driver																																																										
Y	2015	Corvette	Body	Folding Top Control Module																																																										
Y	2015	Corvette	Body	Keyless Entry Control Module																																																										
Y	2015	Corvette	Body	Steering Column Lock Control Module																																																										
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																										
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																										
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Automatic Transmission																																																										
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Manual Transmission																																																										
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Y	2016	Corvette	Powertrain	Rear Differential Clutch Control Module																																																										
Y	2016	Corvette	Chassis	Electronic Brake Control Module																																																										
Y	2016	Corvette	Chassis	Parking Brake Control Module																																																										
Y	2016	Corvette	Chassis	Power Steering Control Module																																																										
Y	2016	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																										
Y	2016	Corvette	Chassis	Suspension Control Module																																																										
Y	2016	Corvette	Body	Body Control Module																																																										
Y	2016	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Y	2016	Corvette	Body	Passenger Presence Module																																																										
Y	2016	Corvette	Body	Instrument Cluster																																																										
Y	2016	Corvette	Body	Radio/HVAC Control																																																										
Y	2016	Corvette	Body	Vehicle Performance Data Recorder																																																										
Y	2016	Corvette	Body	Video Processing Control Module																																																										
Y	2016	Corvette	Body	Inside Rearview Mirror																																																										
Y	2016	Corvette	Body	Radio																																																										
Y	2016	Corvette	Body	Amplifier																																																										
Y	2016	Corvette	Body	Human Machine Interface Control Module																																																										
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2016	Corvette	Body	HVAC Control Module																																																										
Y	2016	Corvette	Body	Liftgate Control Module																																																										
Y	2016	Corvette	Body	Seat Memory Control Module - Passenger																																																										
Y	2016	Corvette	Body	Seat Memory Control Module - Driver																																																										
Y	2016	Corvette	Body	Folding Top Control Module																																																										
Y	2016	Corvette	Body	Keyless Entry Control Module																																																										
Y	2016	Corvette	Body	Steering Column Lock Control Module																																																										
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																										
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																										
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																										
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																										
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																										
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																										
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																										
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																										
Y	2016	Cruze	Chassis	Electronic Brake Control Module																																																										
Y	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																										
Y	2016	Cruze	Chassis	Power Steering Control Module																																																										
Y	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
Y	2016	Cruze	Body	Body Control Module																																																										
Y	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Y	2016	Cruze	Body	Passenger Presence Module																																																										
Y	2016	Cruze	Body	Instrument Cluster																																																										
Y	2016	Cruze	Body	Radio Controls																																																										
Y	2016	Cruze	Body	HVAC Controls																																																										
Y	2016	Cruze	Body	Trailer Interface Control Module																																																										
Y	2016	Cruze	Body	Radio Base (IO3 IO7)																																																										
Y	2016	Cruze	Body	Radio (IOA)																																																										
Y	2016	Cruze	Body	Radio (IOB)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Y	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																										
Y	2016	Cruze	Body	Amplifier																																																										
Y	2016	Cruze	Body	Multimedia Player Interface Module																																																										
Y	2016	Cruze	Body	Human Machine Interface Control Module																																																										
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
Y	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																										
Y	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																										
Y	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																										
Y	2016	Cruze	Body	Keyless Entry Control Module																																																										
Y	2016	Cruze	Body	Right Side Object Detection Control Module																																																										
Y	2016	Cruze	Body	Left Side Object Detection Control Module																																																										
Y	2016	Cruze	Body	Parking Assist Control Module																																																										
Y	2016	Cruze	Body	Frontview Camera Module																																																										
Y	2016	Cruze	Body	Steering Column Lock Control Module																																																										
Y	2016	Cruze	Body	Long Range Radar Sensor Module																																																										
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module					V																																																					
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																										
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Transmission Control Module																																																										
Z	2004	ALL	Chassis	Electronic Brake Control Module													V																																													
Z	2004	ALL	Chassis	Power Steering Control Module																																																										
Z	2004	ALL	Body	Body Control Module			V																																				V																			
Z	2004	ALL	Body	Digital Radio Receiver																																																										
Z	2004	ALL	Body	HVAC Control Module																			V																																							
Z	2004	ALL	Body	Instrument Panel Cluster																																																										
Z	2004	ALL	Body	Radio																																																										
Z	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2004	ALL	Body	Theft Deterrent Module																																																										
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module					V																																																					
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2005	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module					V																																																					
Z	2005	ALL	Chassis	Electronic Brake Control Module													V																																													
Z	2005	ALL	Chassis	Power Steering Control Module																																																										
Z	2005	ALL	Body	Body Control Module			V																																				V																			
Z	2005	ALL	Body	Digital Radio Receiver																																																										
Z	2005	ALL	Body	HVAC Control Module																			V																																							
Z	2005	ALL	Body	Instrument Panel Cluster																																																										
Z	2005	ALL	Body	Radio																																																										
Z	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2005	ALL	Body	Theft Deterrent Module																																																										
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module					V																																																					
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2006	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module					V																																																					
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module					V																																																					
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
Z	2006	ALL	Chassis	Electronic Brake Control Module													V																																													
Z	2006	ALL	Chassis	Power Steering Control Module																																																										
Z	2006	ALL	Body	Body Control Module			V																																				V																			
Z	2006	ALL	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Z	2006	ALL	Body	HVAC Control Module																			V																																					
Z	2006	ALL	Body	Instrument Panel Cluster																																																								
Z	2006	ALL	Body	Radio																																																								
Z	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2006	ALL	Body	Theft Deterrent Module																																																								
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module					V																																																V		
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module					V																																															V			
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																								
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module					V																																															V			
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
Z	2007	ALL	Chassis	Electronic Brake Control Module													V																																											
Z	2007	ALL	Chassis	Power Steering Control Module																																																								
Z	2007	ALL	Body	Body Control Module			V																													V			V				V																	
Z	2007	ALL	Body	Digital Radio Receiver																																																								
Z	2007	ALL	Body	Disc Player and Video Display																																																								
Z	2007	ALL	Body	HVAC Control Module																			V																																					
Z	2007	ALL	Body	Instrument Panel Cluster																																																								
Z	2007	ALL	Body	Radio																																																								
Z	2007	ALL	Body	Remote Control Door Lock Receiver																																																								
Z	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2007	ALL	Body	Theft Deterrent Module																																																								
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module					V																																															V			
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module					V																																																			
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																								
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																								
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module					V																																														V			V
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																								
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																															V			
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
Z	2008	ALL	Chassis	Electronic Brake Control Module											V	V	V																																											
Z	2008	ALL	Chassis	Power Steering Control Module																																																								
Z	2008	ALL	Body	Body Control Module Classic			V																													V			V				V																	
Z	2008	ALL	Body	Body Control Module Malibu			V																													V			V				V																	
Z	2008	ALL	Body	Digital Radio Receiver																																																								
Z	2008	ALL	Body	Disc Player and Video Display																																																								
Z	2008	ALL	Body	HVAC Control Module Classic																			V																																					
Z	2008	ALL	Body	HVAC Control Module Malibu																			V																																					
Z	2008	ALL	Body	Instrument Panel Cluster Classic																																																								
Z	2008	ALL	Body	Instrument Panel Cluster Malibu																																																								
Z	2008	ALL	Body	Radio																																																								
Z	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
Z	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2008	ALL	Body	Theft Deterrent Module																																																								
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module					V																																															V			V
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																								
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																								
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump					V																																														V			V
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump					V																																														V			V
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Without Tap Shift																																																								
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module					V																																														V			V
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																							
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																														V			
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																							
Z	2009	ALL	Chassis	Electronic Brake Control Module											V	V	V																																										
Z	2009	ALL	Chassis	Power Steering Control Module																																																							
Z	2009	ALL	Body	Body Control Module			V																													V			V				V																	
Z	2009	ALL	Body	Digital Radio Receiver																																																							
Z	2009	ALL	Body	Disc Player and Video Display																																																							
Z	2009	ALL	Body	HVAC Control Module																			V																																					
Z	2009	ALL	Body	Instrument Panel Cluster																																																							
Z	2009	ALL	Body	Personal Audio Link Module																																																							
Z	2009	ALL	Body	Radio																																																							
Z	2009	ALL	Body	Supplemental Inflatable Restraint																																																							
Z	2009	ALL	Body	Theft Deterrent Module																																																							
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module					V																																														V			V
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																							
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																							
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Engine Control Module					V																																														V			V
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 6 Speed																																																							
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 4 Speed																																																							
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module					V																																														V			V
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																							
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module					V																																														V			V
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																							
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																														V			
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																							
Z	2010	ALL	Chassis	Electronic Brake Control Module											V	V	V																																										
Z	2010	ALL	Chassis	Power Steering Control Module																																																							
Z	2010	ALL	Body	Body Control Module			V																													V			V				V																	
Z	2010	ALL	Body	Digital Radio Receiver																																																							
Z	2010	ALL	Body	HVAC Control Module																			V																																					
Z	2010	ALL	Body	Instrument Panel Cluster																																																							
Z	2010	ALL	Body	Personal Audio Link Module																																																							
Z	2010	ALL	Body	Radio																																																							
Z	2010	ALL	Body	Supplemental Inflatable Restraint																																																							
Z	2010	ALL	Body	Theft Deterrent Module																																																							
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module					V																																														V			V
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																							
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Engine Control Module					V																																														V			V
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																							
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																														V			
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																							
Z	2011	ALL	Chassis	Electronic Brake Control Module											V	V	V																																										
Z	2011	ALL	Chassis	Power Steering Control Module																																																							
Z	2011	ALL	Body	Body Control Module			V																													V			V				V																	
Z	2011	ALL	Body	Digital Radio Receiver																																																							
Z	2011	ALL	Body	HVAC Control Module																			V																																					
Z	2011	ALL	Body	Instrument Panel Cluster																																																							
Z	2011	ALL	Body	Personal Audio Link Module																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Z	2011	ALL	Body	Radio																																																								
Z	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2011	ALL	Body	Theft Deterrent Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Engine Control Module					V																																															V			V
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Engine Control Module					V																																															V			V
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Engine Control Module					V																																															V			V
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																															V				
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Chassis	Electronic Brake Control Module											V	V	V																																											
Z	2012	Malibu (Seventh Gen)	Chassis	Power Steering Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Body	Body Control Module			V																													V			V				V																	
Z	2012	Malibu (Seventh Gen)	Body	Digital Radio Receiver																																																								
Z	2012	Malibu (Seventh Gen)	Body	HVAC Control Module																			V																																					
Z	2012	Malibu (Seventh Gen)	Body	Instrument Panel Cluster																																																								
Z	2012	Malibu (Seventh Gen)	Body	Personal Audio Link Module																																																								
Z	2012	Malibu (Seventh Gen)	Body	Radio																																																								
Z	2012	Malibu (Seventh Gen)	Body	Supplemental Inflatable Restraint																																																								
Z	2012	Malibu (Seventh Gen)	Body	Theft Deterrent Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Fuel Injector Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Fuel Pump Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Fuel Pump Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	Rear Differential Clutch Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Electronic Brake Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Parking Brake Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Power Steering Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Steering Wheel Angle Sensor Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Suspension Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																								
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																								
Z	2012	Malibu (Eighth Gen)	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Z	2012	Malibu (Eighth Gen)	Body	Instrument Cluster																																																										
Z	2012	Malibu (Eighth Gen)	Body	Head-Up Display Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Headlamp Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Radio																																																										
Z	2012	Malibu (Eighth Gen)	Body	Digital Radio Receiver Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Multimedia Player Interface Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Mobile Telephone Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Dual (CJ2)																																																										
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Single (C68)																																																										
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Manual Single (C67)																																																										
Z	2012	Malibu (Eighth Gen)	Body	Rear Seat Heating Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Keyless Entry Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Right Side Object Detection Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Left Side Object Detection Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Parking Assist Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Vehicle Direction Camera Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Steering Column Lock Control Module																																																										
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Engine Control Module																																																										
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Transmission Control Module																																																										
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Engine Control Module																																																										
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 1																																																										
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 2																																																										
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 6 Speed (MNM)																																																										
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 8 Speed (MRC)																																																										
Z	2016	Malibu	Chassis	Electronic Brake Control Module																																																										
Z	2016	Malibu	Chassis	Brake Booster Control Module																																																										
Z	2016	Malibu	Chassis	Power Steering Control Module																																																										
Z	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
Z	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
Z	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Z	2016	Malibu	Body	Passenger Presence Module																																																										
Z	2016	Malibu	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
Z	2016	Malibu	Body	Instrument Cluster Enhanced Monochrome Driver Info Center (UDC)																																																										
Z	2016	Malibu	Body	Radio Controls																																																										
Z	2016	Malibu	Body	HVAC Controls																																																										
Z	2016	Malibu	Body	Active Safety Control Module																																																										
Z	2016	Malibu	Body	Headlamp Control Module																																																										
Z	2016	Malibu	Body	Radio Base																																																										
Z	2016	Malibu	Body	Radio (IOA)																																																										
Z	2016	Malibu	Body	Radio Uplevel (IO4 IO5 IO6)																																																										
Z	2016	Malibu	Body	Amplifier																																																										
Z	2016	Malibu	Body	Human Machine Interface Control Module																																																										
Z	2016	Malibu	Body	Navigation Control Module																																																										
Z	2016	Malibu	Body	Mobile Telephone Control Module																																																										
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																										
Z	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
Z	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
Z	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
Z	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
Z	2016	Malibu	Body	Electric A/C Compressor Control Module																																																									
Z	2016	Malibu	Body	Seat Memory Control Module - Driver																																																									
Z	2016	Malibu	Body	Keyless Entry Control Module																																																									
Z	2016	Malibu	Body	Right Side Object Detection Control Module																																																									
Z	2016	Malibu	Body	Left Side Object Detection Control Module																																																									
Z	2016	Malibu	Body	Parking Assist Control Module																																																									
Z	2016	Malibu	Body	Frontview Camera Module																																																									
Z	2016	Malibu	Body	Frontview Camera Module																																																									
Z	2016	Malibu	Body	Steering Column Lock Control Module																																																									
Z	2016	Malibu	Body	Long Range Radar Sensor Module																																																									
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
1	2013	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																									
1	2013	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																									
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																									
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																									
1	2013	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																									
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Automatic Transmission																																																									
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Manual Transmission																																																									
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																									
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																									
1	2013	Malibu	Powertrain	2.0L LTD Fuel Pump Control Module																																																									
1	2013	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																									
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																									
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																									
1	2013	Malibu	Powertrain	(X) 2.0L LTG Fuel Pump Control Module																																																									
1	2013	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																									
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
1	2013	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																									
1	2013	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																									
1	2013	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																									
1	2013	Malibu	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																									
1	2013	Malibu	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																																																									
1	2013	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																									
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
1	2013	Malibu	Powertrain	(A) 2.5L LCV Fuel Pump Control Module																																																									
1	2013	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
1	2013	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
1	2013	Malibu	Chassis	Electronic Brake Control Module																																																									
1	2013	Malibu	Chassis	Parking Brake Control Module																																																									
1	2013	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																									
1	2013	Malibu	Chassis	Power Steering Control Module																																																									
1	2013	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2013	Malibu	Chassis	Suspension Control Module																																																									
1	2013	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
1	2013	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																										
1	2013	Malibu	Body	Passenger Presence Module																																																											
1	2013	Malibu	Body	Instrument Cluster																																																											
1	2013	Malibu	Body	Headlamp Control Module																																																											
1	2013	Malibu	Body	Radio																																																											
1	2013	Malibu	Body	Digital Radio Receiver Control Module																																																											
1	2013	Malibu	Body	Multimedia Player Interface Module																																																											
1	2013	Malibu	Body	Mobile Telephone Control Module																																																											
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2013	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
1	2013	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											
1	2013	Malibu	Body	HVAC Control Module Manual Single (C67)																																																											
1	2013	Malibu	Body	Rear Seat Heating Control Module																																																											
1	2013	Malibu	Body	Keyless Entry Control Module																																																											
1	2013	Malibu	Body	Parking Assist Control Module																																																											
1	2013	Malibu	Body	Vehicle Direction Camera Control Module																																																											
1	2013	Malibu	Body	Steering Column Lock Control Module																																																											
1	2013	Malibu	Body	Battery Energy Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																											
1	2014	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																											
1	2014	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																											
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																											
1	2014	Impala	Chassis	Electronic Brake Control Module																																																											
1	2014	Impala	Chassis	Distance Sensing Cruise Control Module																																																											
1	2014	Impala	Chassis	Parking Brake Control Module																																																											
1	2014	Impala	Chassis	Power Steering Control Module																																																											
1	2014	Impala	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2014	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	Impala	Body	Passenger Presence Module																																																											
1	2014	Impala	Body	Instrument Cluster																																																											
1	2014	Impala	Body	Radio Control																																																											
1	2014	Impala	Body	HVAC Control																																																											
1	2014	Impala	Body	Radio																																																											
1	2014	Impala	Body	Amplifier																																																											
1	2014	Impala	Body	Human Machine Interface Control Module																																																											
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Impala	Body	HVAC Control Module																																																											
1	2014	Impala	Body	Keyless Entry Control Module																																																											
1	2014	Impala	Body	Right Side Object Detection Control Module																																																											
1	2014	Impala	Body	Left Side Object Detection Control Module																																																											
1	2014	Impala	Body	Parking Assist Control Module																																																											
1	2014	Impala	Body	Frontview Camera Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2014	Impala	Body	Steering Column Lock Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
1	2014	Malibu	Chassis	Electronic Brake Control Module																																																											
1	2014	Malibu	Chassis	Parking Brake Control Module																																																											
1	2014	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2014	Malibu	Chassis	Power Steering Control Module																																																											
1	2014	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Malibu	Chassis	Suspension Control Module																																																											
1	2014	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2014	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																											
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																											
1	2014	Malibu	Body	Passenger Presence Module																																																											
1	2014	Malibu	Body	Instrument Cluster																																																											
1	2014	Malibu	Body	Headlamp Control Module																																																											
1	2014	Malibu	Body	Radio																																																											
1	2014	Malibu	Body	Digital Radio Receiver Control Module																																																											
1	2014	Malibu	Body	Multimedia Player Interface Module																																																											
1	2014	Malibu	Body	Mobile Telephone Control Module																																																											
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
1	2014	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2014	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2014	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
1	2014	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2014	Malibu	Body	Keyless Entry Control Module																																																										
1	2014	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2014	Malibu	Body	Parking Assist Control Module																																																										
1	2014	Malibu	Body	Frontview Camera Module																																																										
1	2014	Malibu	Body	Steering Column Lock Control Module																																																										
1	2015	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																										
1	2015	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																										
1	2015	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																										
1	2015	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																										
1	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																										
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																										
1	2015	Impala	Chassis	Electronic Brake Control Module																																																										
1	2015	Impala	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Impala	Chassis	Parking Brake Control Module																																																										
1	2015	Impala	Chassis	Power Steering Control Module																																																										
1	2015	Impala	Chassis	Power Steering Control Module																																																										
1	2015	Impala	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2015	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Impala	Body	Passenger Presence Module																																																										
1	2015	Impala	Body	Instrument Cluster																																																										
1	2015	Impala	Body	Radio Control																																																										
1	2015	Impala	Body	HVAC Control																																																										
1	2015	Impala	Body	Radio																																																										
1	2015	Impala	Body	Amplifier																																																										
1	2015	Impala	Body	Human Machine Interface Control Module																																																										
1	2015	Impala	Body	Telematics Communication Interface Control Module																																																										
1	2015	Impala	Body	HVAC Control Module																																																										
1	2015	Impala	Body	Keyless Entry Control Module																																																										
1	2015	Impala	Body	Right Side Object Detection Control Module																																																										
1	2015	Impala	Body	Left Side Object Detection Control Module																																																										
1	2015	Impala	Body	Parking Assist Control Module																																																										
1	2015	Impala	Body	Frontview Camera Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Chassis Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBS Chassis Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2015	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																										
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																										
1	2015	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.4L LE9 Chassis Control Module																																																										
1	2015	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2015	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																										
1	2015	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																										
1	2015	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																										
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																										
1	2015	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																										
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	3.0L LFW Chassis Control Module																																																										
1	2015	Malibu	Powertrain	3.0L LFW Transmission Control Module																																																										
1	2015	Malibu	Powertrain	Rear Differential Clutch Control Module																																																										
1	2015	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2015	Malibu	Chassis	Parking Brake Control Module																																																										
1	2015	Malibu	Chassis	Power Steering Control Module																																																										
1	2015	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2015	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2015	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Malibu	Body	Passenger Presence Module																																																										
1	2015	Malibu	Body	Instrument Cluster																																																										
1	2015	Malibu	Body	Headlamp Control Module																																																										
1	2015	Malibu	Body	Radio																																																										
1	2015	Malibu	Body	Digital Radio Receiver Control Module																																																										
1	2015	Malibu	Body	Multimedia Player Interface Module																																																										
1	2015	Malibu	Body	Mobile Telephone Control Module																																																										
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
1	2015	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
1	2015	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2015	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
1	2015	Malibu	Body	Front Seat Heating Control Module																																																										
1	2015	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2015	Malibu	Body	Keyless Entry Control Module																																																										
1	2015	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2015	Malibu	Body	Parking Assist Control Module																																																										
1	2015	Malibu	Body	Frontview Camera Module																																																										
1	2015	Malibu	Body	Steering Column Lock Control Module																																																										
1	2015	Malibu (LSG)	Powertrain	1.6L LLU Engine Control Module																																																										
1	2015	Malibu (LSG)	Powertrain	Transmission Control Module																																																										
1	2015	Malibu (LSG)	Powertrain	Rear Differential Clutch Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2015	Malibu (LSG)	Chassis	Electronic Brake Control Module																																																										
1	2015	Malibu (LSG)	Chassis	Parking Brake Control Module																																																										
1	2015	Malibu (LSG)	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Malibu (LSG)	Chassis	Suspension Control Module																																																										
1	2015	Malibu (LSG)	Body	Body Control Module																																																										
1	2015	Malibu (LSG)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Malibu (LSG)	Body	Instrument Cluster																																																										
1	2015	Malibu (LSG)	Body	Headlamp Control Module																																																										
1	2015	Malibu (LSG)	Body	Radio																																																										
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Malibu (LSG)	Body	HVAC Control Module																																																										
1	2015	Malibu (LSG)	Body	Front Seat Heating Control Module																																																										
1	2015	Malibu (LSG)	Body	Keyless Entry Control Module																																																										
1	2015	Malibu (LSG)	Body	Left Side Object Detection Control Module																																																										
1	2015	Malibu (LSG)	Body	Parking Assist Control Module																																																										
1	2015	Malibu (LSG)	Body	Frontview Camera Module																																																										
1	2015	Malibu (LSG)	Body	Steering Column Lock Control Module																																																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2016	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																										
1	2016	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																										
1	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2016	Impala	Powertrain	Chassis Control Module																																																										
1	2016	Impala	Chassis	Electronic Brake Control Module																																																										
1	2016	Impala	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Impala	Chassis	Parking Brake Control Module																																																										
1	2016	Impala	Chassis	Power Steering Control Module																																																										
1	2016	Impala	Chassis	Power Steering Control Module																																																										
1	2016	Impala	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2016	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Impala	Body	Passenger Presence Module																																																										
1	2016	Impala	Body	Instrument Cluster																																																										
1	2016	Impala	Body	Radio Control																																																										
1	2016	Impala	Body	HVAC Control																																																										
1	2016	Impala	Body	Radio																																																										
1	2016	Impala	Body	Amplifier																																																										
1	2016	Impala	Body	Human Machine Interface Control Module																																																										
1	2016	Impala	Body	Navigation Control Module																																																										
1	2016	Impala	Body	Telematics Communication Interface Control Module																																																										
1	2016	Impala	Body	HVAC Control Module																																																										
1	2016	Impala	Body	Seat Memory Control Module - Driver																																																										
1	2016	Impala	Body	Keyless Entry Control Module																																																										
1	2016	Impala	Body	Right Side Object Detection Control Module																																																										
1	2016	Impala	Body	Left Side Object Detection Control Module																																																										
1	2016	Impala	Body	Parking Assist Control Module																																																										
1	2016	Impala	Body	Frontview Camera Module																																																										
1	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2016	Malibu	Powertrain	Fuel Injector Control Module																																																										
1	2016	Malibu	Powertrain	Chassis Control Module																																																										
1	2016	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2016	Malibu	Chassis	Parking Brake Control Module																																																										
1	2016	Malibu	Chassis	Power Steering Control Module																																																										
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Malibu	Body	Passenger Presence Module																																																										
1	2016	Malibu	Body	Instrument Cluster																																																										
1	2016	Malibu	Body	Headlamp Control Module																																																										
1	2016	Malibu	Body	Radio																																																										
1	2016	Malibu	Body	Digital Radio Receiver Control Module																																																										
1	2016	Malibu	Body	Multimedia Player Interface Module																																																										
1	2016	Malibu	Body	Mobile Telephone Control Module																																																										
1	2016	Malibu	Body	Telematics Communication Interface Control Module																																																										
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
1	2016	Malibu	Body	Seat Memory Control Module																																																										
1	2016	Malibu	Body	Front Seat Heating Control Module																																																										
1	2016	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2016	Malibu	Body	Keyless Entry Control Module																																																										
1	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2016	Malibu	Body	Parking Assist Control Module																																																										
1	2016	Malibu	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2005	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																										
A	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module										V																																																
A	2005	ALL	Powertrain	Transmission Control Module																																																											
A	2005	ALL	Chassis	Power Steering Control Module																																																											
A	2005	ALL	Chassis	Anti-lock Brake System																																																											
A	2005	ALL	Body	Body Control Module																					V		V			V																																	
A	2005	ALL	Body	Digital Radio Receiver																																																										
A	2005	ALL	Body	Instrument Panel																																																										
A	2005	ALL	Body	Radio																																																										
A	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2006	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																											
A	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module										V																																																
A	2006	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module	V																																																										
A	2006	ALL	Powertrain	Transmission Control Module																																																											
A	2006	ALL	Chassis	Power Steering Control Module																																																											
A	2006	ALL	Chassis	Anti-lock Brake System																																																											
A	2006	ALL	Body	Body Control Module																					V		V			V																																	
A	2006	ALL	Body	Digital Radio Receiver																																																										
A	2006	ALL	Body	Instrument Panel																																																										
A	2006	ALL	Body	Radio																																																										
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2006	ALL	Body	Theft Deterrent Module																																																											
A	2007	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																											
A	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module										V																																																
A	2007	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module	V																																																										
A	2007	ALL	Powertrain	Transmission Control Module																																																											
A	2007	ALL	Chassis	Power Steering Control Module																																																											
A	2007	ALL	Chassis	Electronic Brake Control Module																																																											
A	2007	ALL	Body	Body Control Module																					V		V			V																																	
A	2007	ALL	Body	Digital Radio Receiver																																																										
A	2007	ALL	Body	Instrument Panel Cluster																																																											
A	2007	ALL	Body	Passenger Presence System																																																											
A	2007	ALL	Body	Personal Audio Link Module																																																											
A	2007	ALL	Body	Radio																																																										
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
A	2007	ALL	Body	Theft Deterrent Module																																																											
A	2008	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module				V						V																																																	
A	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module	V									V																																																	
A	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module	V																																																										
A	2008	ALL	Powertrain	Transmission Control Module																																																											
A	2008	ALL	Chassis	Power Steering Control Module																																																											
A	2008	ALL	Chassis	Electronic Brake Control Module with VSES																																																											
A	2008	ALL	Chassis	Electronic Brake Control Module without VSES																																																											
A	2008	ALL	Body	Body Control Module																					V	V	V			V																																	
A	2008	ALL	Body	Digital Radio Receiver																																																										
A	2008	ALL	Body	Instrument Panel Cluster																																																											
A	2008	ALL	Body	Passenger Presence System																																																											
A	2008	ALL	Body	Personal Audio Link Module																																																											
A	2008	ALL	Body	Radio																																																										
A	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
A	2008	ALL	Body	Theft Deterrent Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2009	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module				V						V																																																
A	2009	ALL	Powertrain	(H)2.2L L4 LAP Engine Control Module	V			V																																																						
A	2009	ALL	Powertrain	Transmission Control Module																																																										
A	2009	ALL	Chassis	Power Steering Control Module																																																										
A	2009	ALL	Chassis	Electronic Brake Control Module with VSES																																																										
A	2009	ALL	Chassis	Electronic Brake Control Module without VSES																																																										
A	2009	ALL	Body	Body Control Module																					V	V		V			V																																
A	2009	ALL	Body	Digital Radio Receiver																																																										
A	2009	ALL	Body	Instrument Panel Cluster																																																										
A	2009	ALL	Body	Passenger Presence System																																																										
A	2009	ALL	Body	Personal Audio Link Module																																																										
A	2009	ALL	Body	Radio																																																										
A	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2009	ALL	Body	Theft Deterrent Module																																																										
A	2010	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module				V																																																						
A	2010	ALL	Powertrain	(5)2.2L L4 LAP Engine Control Module	V			V																																																						
A	2010	ALL	Powertrain	Transmission Control Module																																																										
A	2010	ALL	Chassis	Power Steering Control Module																																																										
A	2010	ALL	Chassis	Electronic Brake Control Module with VSES																																																										
A	2010	ALL	Chassis	Electronic Brake Control Module without VSES																																																										
A	2010	ALL	Body	Body Control Module																					V	V		V			V																																
A	2010	ALL	Body	Digital Radio Receiver																																																										
A	2010	ALL	Body	Driver Information Center																																																										
A	2010	ALL	Body	Instrument Panel Cluster																																																										
A	2010	ALL	Body	Passenger Presence System																																																										
A	2010	ALL	Body	Personal Audio Link Module																																																										
A	2010	ALL	Body	Radio																																																										
A	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2010	ALL	Body	Theft Deterrent Module																																																										
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																										
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
A	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																										
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2012	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																										
A	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2012	Cobalt	Body	Body Control Module																																																										
A	2012	Cobalt	Body	Passenger Presence Module																																																										
A	2012	Cobalt	Body	Instrument Cluster																																																										
A	2012	Cobalt	Body	Radio																																																										
A	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
A	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																										
A	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2012	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2012	Cobalt	Body	Parking Assist Control Module																																																										
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2013	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	Cobalt	Body	Body Control Module																																																										
A	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	Cobalt	Body	Instrument Cluster																																																										
A	2013	Cobalt	Body	Radio																																																										
A	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																										
A	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
A	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2013	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2013	Cobalt	Body	Parking Assist Control Module																																																										
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2014	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	Cobalt	Body	Body Control Module																																																										
A	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	Cobalt	Body	Instrument Cluster																																																										
A	2014	Cobalt	Body	Radio																																																										
A	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2014	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2014	Cobalt	Body	Parking Assist Control Module																																																										
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2015	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	Cobalt	Body	Body Control Module																																																										
A	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	Cobalt	Body	Instrument Cluster																																																										
A	2015	Cobalt	Body	Radio																																																										
A	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																										
A	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
A	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2015	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2015	Cobalt	Body	Parking Assist Control Module																																																										
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2016	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	Cobalt	Body	Body Control Module																																																										
A	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	Cobalt	Body	Instrument Cluster																																																										
A	2016	Cobalt	Body	Radio Other																																																										
A	2016	Cobalt	Body	Radio (IOB)																																																										
A	2016	Cobalt	Body	Radio (UF7)																																																										
A	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2016	Cobalt	Body	Front Seat Heating Control Module																																																										
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																										
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																										
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2010	Beat	Powertrain	Transmission Control Module																																																										
B	2010	Beat	Chassis	Electronic Brake Control Module																																																										
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2010	Beat	Chassis	Power Steering Control Module																																																										
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2010	Beat	Body	Instrument Cluster																																																										
B	2010	Beat	Body	Keyless Entry Control Module																																																										
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																										
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																										
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2011	Beat	Powertrain	Transmission Control Module																																																										
B	2011	Beat	Chassis	Electronic Brake Control Module																																																										
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2011	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2011	Beat	Body	Instrument Cluster																																																										
B	2011	Beat	Body	Keyless Entry Control Module																																																										
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2012	Beat	Powertrain	Transmission Control Module																																																										
B	2012	Beat	Chassis	Electronic Brake Control Module																																																										
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2012	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2012	Beat	Body	Instrument Cluster																																																										
B	2012	Beat	Body	Keyless Entry Control Module																																																										
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2013	Beat	Powertrain	Transmission Control Module																																																										
B	2013	Beat	Chassis	Electronic Brake Control Module																																																										
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2013	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2013	Beat	Body	Instrument Cluster																																																										
B	2013	Beat	Body	Keyless Entry Control Module																																																										
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2014	Beat	Powertrain	Transmission Control Module																																																										
B	2014	Beat	Powertrain	Fuel Injector Control Module																																																										
B	2014	Beat	Chassis	Electronic Brake Control Module																																																										
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
B	2014	Beat	Chassis	Power Steering Control Module																																																										
B	2014	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2014	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2014	Beat	Body	Instrument Cluster																																																										
B	2014	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2015	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2015	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2015	Beat	Powertrain	Transmission Control Module																																																										
B	2015	Beat	Powertrain	Fuel Injector Control Module																																																										
B	2015	Beat	Chassis	Electronic Brake Control Module																																																										
B	2015	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2015	Beat	Chassis	Power Steering Control Module																																																										
B	2015	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2015	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2015	Beat	Body	Instrument Cluster																																																										
B	2015	Beat	Body	Radio																																																										
B	2015	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2015	Beat	Body	Keyless Entry Control Module																																																										
B	2016	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2016	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2016	Beat	Powertrain	Transmission Control Module																																																										
B	2016	Beat	Chassis	Electronic Brake Control Module																																																										
B	2016	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2016	Beat	Chassis	Power Steering Control Module																																																										
B	2016	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2016	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2016	Beat	Body	Instrument Cluster																																																										
B	2016	Beat	Body	Radio																																																										
B	2016	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2016	Beat	Body	HVAC Control Module																																																										
B	2016	Beat	Body	Keyless Entry Control Module																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																										
B	2016	Cruze	Chassis	Electronic Brake Control Module																																																										
B	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																										
B	2016	Cruze	Chassis	Power Steering Control Module																																																										
B	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2016	Cruze	Body	Body Control Module																																																										
B	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2016	Cruze	Body	Passenger Presence Module																																																										
B	2016	Cruze	Body	Instrument Cluster																																																										
B	2016	Cruze	Body	Radio Controls																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
B	2016	Cruze	Body	HVAC Controls																																																										
B	2016	Cruze	Body	Trailer Interface Control Module																																																											
B	2016	Cruze	Body	Radio Base (IO3 IO7)																																																											
B	2016	Cruze	Body	Radio (IOA)																																																											
B	2016	Cruze	Body	Radio (IOB)																																																											
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																											
B	2016	Cruze	Body	Amplifier																																																											
B	2016	Cruze	Body	Multimedia Player Interface Module																																																											
B	2016	Cruze	Body	Human Machine Interface Control Module																																																											
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																											
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																											
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																											
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																											
B	2016	Cruze	Body	Keyless Entry Control Module																																																											
B	2016	Cruze	Body	Right Side Object Detection Control Module																																																											
B	2016	Cruze	Body	Left Side Object Detection Control Module																																																											
B	2016	Cruze	Body	Parking Assist Control Module																																																											
B	2016	Cruze	Body	Frontview Camera Module																																																											
B	2016	Cruze	Body	Steering Column Lock Control Module																																																											
B	2016	Cruze	Body	Long Range Radar Sensor Module																																																											
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2010	Spark	Powertrain	Transmission Control Module																																																											
C	2010	Spark	Chassis	Electronic Brake Control Module																																																											
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2010	Spark	Chassis	Electric Power Steering Control Module																																																											
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2010	Spark	Body	Passenger Presence Module																																																											
C	2010	Spark	Body	Instrument Cluster																																																											
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																											
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																											
C	2011	Spark	Powertrain	Transmission Control Module																																																											
C	2011	Spark	Chassis	Electronic Brake Control Module																																																											
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2011	Spark	Chassis	Electric Power Steering Control Module																																																											
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2011	Spark	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2011	Spark	Body	Instrument Cluster																																																										
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																											
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																											
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																											
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																											
C	2012	Spark	Powertrain	Transmission Control Module																																																											
C	2012	Spark	Chassis	Electronic Brake Control Module																																																											
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2012	Spark	Chassis	Electric Power Steering Control Module																																																											
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2012	Spark	Body	Passenger Presence Module																																																											
C	2012	Spark	Body	Instrument Cluster																																																											
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																											
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																											
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																											
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																											
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2013	Spark	Powertrain	Fuel Injector Control Module																																																											
C	2013	Spark	Chassis	Electronic Brake Control Module																																																											
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2013	Spark	Chassis	Power Steering Control Module																																																											
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2013	Spark	Body	Body Control Module																																																											
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2013	Spark	Body	Passenger Presence Module																																																											
C	2013	Spark	Body	Instrument Cluster																																																											
C	2013	Spark	Body	Radio																																																											
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																											
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
C	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
C	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
C	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2014	Spark	Chassis	Electronic Brake Control Module																																																										
C	2014	Spark	Chassis	Electronic Brake Control Module																																																										
C	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2014	Spark	Chassis	Power Steering Control Module																																																										
C	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Spark	Body	Body Control Module																																																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark	Body	Passenger Presence Module																																																										
C	2014	Spark	Body	Instrument Cluster																																																										
C	2014	Spark	Body	Radio																																																										
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Spark	Body	Keyless Entry Control Module																																																										
C	2014	Spark EV	Powertrain	Engine Control Module																																																										
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
C	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
C	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
C	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
C	2014	Spark EV	Chassis	Power Steering Control Module																																																										
C	2014	Spark EV	Body	Body Control Module																																																										
C	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark EV	Body	Passenger Presence Module																																																										
C	2014	Spark EV	Body	Instrument Cluster																																																										
C	2014	Spark EV	Body	Radio																																																										
C	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Spark EV	Body	HVAC Control Module																																																										
C	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2014	Spark EV	Body	Coolant Heater Control Module																																																										
C	2014	Spark EV	Body	Keyless Entry Control Module																																																										
C	2014	Spark EV	Body	Battery Charger Control Module																																																										
C	2014	Spark EV	Body	DC Charging Control Module																																																										
C	2014	Spark EV	Body	Battery Energy Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
C	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Spark	Chassis	Power Steering Control Module																																																										
C	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Spark	Body	Body Control Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Passenger Presence Module																																																										
C	2015	Spark	Body	Instrument Cluster																																																										
C	2015	Spark	Body	Instrument Cluster																																																										
C	2015	Spark	Body	Tire Pressure Indicator Module																																																										
C	2015	Spark	Body	Radio																																																										
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Spark	Body	Keyless Entry Control Module																																																										
C	2015	Spark EV	Powertrain	Engine Control Module																																																										
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
C	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
C	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
C	2015	Spark EV	Chassis	Power Steering Control Module																																																										
C	2015	Spark EV	Body	Body Control Module																																																										
C	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark EV	Body	Passenger Presence Module																																																										
C	2015	Spark EV	Body	Instrument Cluster																																																										
C	2015	Spark EV	Body	Radio																																																										
C	2015	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2015	Spark EV	Body	Coolant Heater Control Module																																																											
C	2015	Spark EV	Body	Keyless Entry Control Module																																																											
C	2015	Spark EV	Body	Battery Charger Control Module																																																											
C	2015	Spark EV	Body	DC Charging Control Module																																																											
C	2015	Spark EV	Body	Battery Energy Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	Fuel Injector Control Module																																																											
C	2016	Spark	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2016	Spark	Chassis	Power Steering Control Module																																																											
C	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Spark	Body	Body Control Module																																																											
C	2016	Spark	Body	Body Control Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Instrument Cluster																																																											
C	2016	Spark	Body	Instrument Cluster																																																											
C	2016	Spark	Body	Radio																																																											
C	2016	Spark	Body	Telematics Communication Interface Control Module																																																											
C	2016	Spark	Body	Keyless Entry Control Module																																																											
C	2016	Spark EV	Powertrain	Engine Control Module																																																											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
C	2016	Spark EV	Powertrain	Drive Motor Control Module																																																											
C	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
C	2016	Spark EV	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark EV	Chassis	Parking Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2016	Spark EV	Chassis	Power Steering Control Module																																																										
C	2016	Spark EV	Body	Body Control Module																																																										
C	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Spark EV	Body	Passenger Presence Module																																																										
C	2016	Spark EV	Body	Instrument Cluster																																																										
C	2016	Spark EV	Body	Radio																																																										
C	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
C	2016	Spark EV	Body	HVAC Control Module																																																										
C	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2016	Spark EV	Body	Coolant Heater Control Module																																																										
C	2016	Spark EV	Body	Keyless Entry Control Module																																																										
C	2016	Spark EV	Body	Frontview Camera Module																																																										
C	2016	Spark EV	Body	Battery Charger Control Module																																																										
C	2016	Spark EV	Body	DC Charging Control Module																																																										
C	2016	Spark EV	Body	Battery Energy Control Module																																																										
D	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2010	Spark	Powertrain	Transmission Control Module																																																										
D	2010	Spark	Chassis	Electronic Brake Control Module																																																										
D	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2010	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2010	Spark	Body	Passenger Presence Module																																																										
D	2010	Spark	Body	Instrument Cluster																																																										
D	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										
D	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
D	2011	Spark	Powertrain	Transmission Control Module																																																										
D	2011	Spark	Chassis	Electronic Brake Control Module																																																										
D	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2011	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2011	Spark	Body	Passenger Presence Module																																																										
D	2011	Spark	Body	Instrument Cluster																																																										
D	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										
D	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
D	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
D	2012	Spark	Powertrain	Transmission Control Module																																																										
D	2012	Spark	Chassis	Electronic Brake Control Module																																																										
D	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2012	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2012	Spark	Body	Passenger Presence Module																																																										
D	2012	Spark	Body	Instrument Cluster																																																										
D	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										
D	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																										
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
D	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
D	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																										
D	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2013	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2013	Spark	Chassis	Electronic Brake Control Module																																																										
D	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2013	Spark	Chassis	Power Steering Control Module																																																										
D	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2013	Spark	Body	Body Control Module																																																										
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2013	Spark	Body	Passenger Presence Module																																																										
D	2013	Spark	Body	Instrument Cluster																																																										
D	2013	Spark	Body	Radio																																																										
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
D	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
D	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
D	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
D	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2014	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2014	Spark	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2014	Spark	Chassis	Power Steering Control Module																																																											
D	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2014	Spark	Body	Body Control Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Passenger Presence Module																																																											
D	2014	Spark	Body	Instrument Cluster																																																											
D	2014	Spark	Body	Radio																																																											
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark	Body	Keyless Entry Control Module																																																											
D	2014	Spark EV	Powertrain	Engine Control Module																																																											
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
D	2014	Spark EV	Powertrain	Drive Motor Control Module																																																											
D	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
D	2014	Spark EV	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark EV	Chassis	Parking Brake Control Module																																																											
D	2014	Spark EV	Chassis	Power Steering Control Module																																																											
D	2014	Spark EV	Body	Body Control Module																																																											
D	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
D	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark EV	Body	Passenger Presence Module																																																											
D	2014	Spark EV	Body	Instrument Cluster																																																											
D	2014	Spark EV	Body	Radio																																																											
D	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark EV	Body	HVAC Control Module																																																											
D	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																											
D	2014	Spark EV	Body	Coolant Heater Control Module																																																											
D	2014	Spark EV	Body	Keyless Entry Control Module																																																											
D	2014	Spark EV	Body	Battery Charger Control Module																																																											
D	2014	Spark EV	Body	DC Charging Control Module																																																											
D	2014	Spark EV	Body	Battery Energy Control Module																																																											
D	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
D	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
D	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2015	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2015	Spark	Chassis	Electronic Brake Control Module																																																											
D	2015	Spark	Chassis	Electronic Brake Control Module																																																											
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2015	Spark	Chassis	Power Steering Control Module																																																											
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2015	Spark	Body	Body Control Module																																																											
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark	Body	Passenger Presence Module																																																											
D	2015	Spark	Body	Instrument Cluster																																																											
D	2015	Spark	Body	Instrument Cluster																																																											
D	2015	Spark	Body	Tire Pressure Indicator Module																																																											
D	2015	Spark	Body	Radio																																																											
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2015	Spark	Body	Keyless Entry Control Module																																																											
D	2015	Spark EV	Powertrain	Engine Control Module																																																											
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
D	2015	Spark EV	Powertrain	Drive Motor Control Module																																																											
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
D	2015	Spark EV	Chassis	Electronic Brake Control Module																																																											
D	2015	Spark EV	Chassis	Parking Brake Control Module																																																											
D	2015	Spark EV	Chassis	Power Steering Control Module																																																											
D	2015	Spark EV	Body	Body Control Module																																																											
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark EV	Body	Passenger Presence Module																																																											
D	2015	Spark EV	Body	Instrument Cluster																																																											
D	2015	Spark EV	Body	Radio																																																											
D	2015	Spark EV	Body	HVAC Control Module																																																											
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																											
D	2015	Spark EV	Body	Coolant Heater Control Module																																																											
D	2015	Spark EV	Body	Keyless Entry Control Module																																																											
D	2015	Spark EV	Body	Battery Charger Control Module																																																											
D	2015	Spark EV	Body	DC Charging Control Module																																																											
D	2015	Spark EV	Body	Battery Energy Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
D	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2016	Spark	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2016	Spark	Chassis	Power Steering Control Module																																																										
D	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2016	Spark	Body	Body Control Module																																																										
D	2016	Spark	Body	Body Control Module																																																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark	Body	Instrument Cluster																																																										
D	2016	Spark	Body	Instrument Cluster																																																										
D	2016	Spark	Body	Radio																																																										
D	2016	Spark	Body	Telematics Communication Interface Control Module																																																										
D	2016	Spark	Body	Keyless Entry Control Module																																																										
D	2016	Spark EV	Powertrain	Engine Control Module																																																										
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
D	2016	Spark EV	Powertrain	Drive Motor Control Module																																																										
D	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
D	2016	Spark EV	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark EV	Chassis	Parking Brake Control Module																																																										
D	2016	Spark EV	Chassis	Power Steering Control Module																																																										
D	2016	Spark EV	Body	Body Control Module																																																										
D	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
D	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark EV	Body	Passenger Presence Module																																																										
D	2016	Spark EV	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2016	Spark EV	Body	Radio																																																												
D	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																												
D	2016	Spark EV	Body	HVAC Control Module																																																												
D	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																												
D	2016	Spark EV	Body	Coolant Heater Control Module																																																												
D	2016	Spark EV	Body	Keyless Entry Control Module																																																												
D	2016	Spark EV	Body	Frontview Camera Module																																																												
D	2016	Spark EV	Body	Battery Charger Control Module																																																												
D	2016	Spark EV	Body	DC Charging Control Module																																																												
D	2016	Spark EV	Body	Battery Energy Control Module																																																												
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Automatic Transmission																																																												
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Manual Transmission																																																												
F	2010	Camaro	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																												
F	2010	Camaro	Powertrain	(V) 3.6L LLT Transmission Control Module																																																												
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2010	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																												
F	2010	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																												
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2010	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2010	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2010	Camaro	Chassis	Power Steering Control Module																																																												
F	2010	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2010	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2010	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2010	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2010	Camaro	Body	Passenger Presence Module																																																												
F	2010	Camaro	Body	Instrument Cluster																																																												
F	2010	Camaro	Body	Auxiliary Gage Module																																																												
F	2010	Camaro	Body	Radio																																																												
F	2010	Camaro	Body	Multimedia Player Interface Module																																																												
F	2010	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																												
F	2010	Camaro	Body	Mobile Telephone Control Module																																																												
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2010	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																												
F	2010	Camaro	Body	Front Seat Heating Control Module																																																												
F	2010	Camaro	Body	Folding Top Control Module																																																												
F	2010	Camaro	Body	Parking Assist Control Module																																																												
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Automatic Transmission																																																												
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Manual Transmission																																																												
F	2011	Camaro	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																												
F	2011	Camaro	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2011	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																												
F	2011	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																											
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2011	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2011	Camaro	Chassis	Power Steering Control Module																																																											
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2011	Camaro	Body	Passenger Presence Module																																																												
F	2011	Camaro	Body	Instrument Cluster																																																												
F	2011	Camaro	Body	Head-Up Display Module																																																												
F	2011	Camaro	Body	Auxiliary Gage Module																																																												
F	2011	Camaro	Body	Headlamp Control Module																																																												
F	2011	Camaro	Body	Radio																																																											
F	2011	Camaro	Body	Multimedia Player Interface Module																																																											
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																											
F	2011	Camaro	Body	Mobile Telephone Control Module																																																											
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																											
F	2011	Camaro	Body	Front Seat Heating Control Module																																																											
F	2011	Camaro	Body	Folding Top Control Module																																																											
F	2011	Camaro	Body	Parking Assist Control Module																																																											
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																											
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																											
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																											
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																											
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module																																																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																											
F	2012	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2012	Camaro	Chassis	Power Steering Control Module																																																											
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2012	Camaro	Chassis	Suspension Control Module																																																											
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2012	Camaro	Body	Passenger Presence Module																																																											
F	2012	Camaro	Body	Instrument Cluster																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
F	2012	Camaro	Body	Head-Up Display Module																																																											
F	2012	Camaro	Body	Auxiliary Gage Module																																																												
F	2012	Camaro	Body	Headlamp Control Module																																																												
F	2012	Camaro	Body	Radio																																																												
F	2012	Camaro	Body	Multimedia Player Interface Module																																																												
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																												
F	2012	Camaro	Body	Mobile Telephone Control Module																																																												
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																												
F	2012	Camaro	Body	Front Seat Heating Control Module																																																												
F	2012	Camaro	Body	Folding Top Control Module																																																												
F	2012	Camaro	Body	Parking Assist Control Module																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																												
F	2013	Camaro	Chassis	Electronic Brake Control Module																																																													
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2013	Camaro	Chassis	Power Steering Control Module																																																												
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2013	Camaro	Chassis	Suspension Control Module																																																												
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2013	Camaro	Body	Passenger Presence Module																																																												
F	2013	Camaro	Body	Instrument Cluster																																																												
F	2013	Camaro	Body	Head-Up Display Module																																																												
F	2013	Camaro	Body	Auxiliary Gage Module																																																												
F	2013	Camaro	Body	Headlamp Control Module																																																												
F	2013	Camaro	Body	Radio																																																											
F	2013	Camaro	Body	Multimedia Player Interface Module																																																												
F	2013	Camaro	Body	Mobile Telephone Control Module																																																												
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
F	2013	Camaro	Body	HVAC Control Module																																																											
F	2013	Camaro	Body	Front Seat Heating Control Module																																																												
F	2013	Camaro	Body	Folding Top Control Module																																																												
F	2013	Camaro	Body	Parking Assist Control Module																																																												
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																												
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																												
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																												
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																												
F	2014	Camaro	Powertrain	Transmission Control Module																																																												
F	2014	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2014	Camaro	Chassis	Parking Brake Control Module																																																												
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2014	Camaro	Chassis	Power Steering Control Module																																																												
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2014	Camaro	Chassis	Suspension Control Module																																																												
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2014	Camaro	Body	Passenger Presence Module																																																												
F	2014	Camaro	Body	Instrument Cluster																																																												
F	2014	Camaro	Body	Head-Up Display Module																																																												
F	2014	Camaro	Body	Auxiliary Gage Module																																																												
F	2014	Camaro	Body	Headlamp Control Module																																																												
F	2014	Camaro	Body	Radio																																																											
F	2014	Camaro	Body	Mobile Telephone Control Module																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2014	Camaro	Body	HVAC Control Module																																																											
F	2014	Camaro	Body	Front Seat Heating Control Module																																																											
F	2014	Camaro	Body	Folding Top Control Module																																																											
F	2014	Camaro	Body	Parking Assist Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2014	SS	Powertrain	Chassis Control Module																																																											
F	2014	SS	Chassis	Electronic Brake Control Module																																																											
F	2014	SS	Chassis	Parking Brake Control Module																																																											
F	2014	SS	Chassis	Power Steering Control Module																																																											
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2014	SS	Body	Body Control Module																																																											
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2014	SS	Body	Passenger Presence Module																																																											
F	2014	SS	Body	Instrument Cluster																																																											
F	2014	SS	Body	Head-Up Display Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
F	2014	SS	Body	Radio Control																																																										
F	2014	SS	Body	HVAC Control																																																										
F	2014	SS	Body	Headlamp Control Module																																																										
F	2014	SS	Body	Trailer Interface Control Module																																																										
F	2014	SS	Body	Radio																																																										
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2014	SS	Body	HVAC Control Module																																																										
F	2014	SS	Body	Seat Memory Control Module - Driver																																																										
F	2014	SS	Body	Keyless Entry Control Module																																																										
F	2014	SS	Body	Right Side Object Detection Control Module																																																										
F	2014	SS	Body	Left Side Object Detection Control Module																																																										
F	2014	SS	Body	Parking Assist Control Module																																																										
F	2014	SS	Body	Frontview Camera Module																																																										
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																										
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																										
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																										
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																										
F	2015	Camaro	Powertrain	Transmission Control Module																																																										
F	2015	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2015	Camaro	Chassis	Power Steering Control Module																																																										
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2015	Camaro	Chassis	Suspension Control Module																																																										
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2015	Camaro	Body	Passenger Presence Module																																																										
F	2015	Camaro	Body	Instrument Cluster																																																										
F	2015	Camaro	Body	Head-Up Display Module																																																										
F	2015	Camaro	Body	Auxiliary Gage Module																																																										
F	2015	Camaro	Body	Headlamp Control Module																																																										
F	2015	Camaro	Body	Radio																																																										
F	2015	Camaro	Body	Mobile Telephone Control Module																																																										
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6																																																										
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																										
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2015	Camaro	Body	HVAC Control Module																																																										
F	2015	Camaro	Body	Front Seat Heating Control Module																																																										
F	2015	Camaro	Body	Folding Top Control Module																																																										
F	2015	Camaro	Body	Parking Assist Control Module																																																										
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2015	SS	Powertrain	Fuel Injector Control Module																																																											
F	2015	SS	Powertrain	Chassis Control Module																																																											
F	2015	SS	Chassis	Electronic Brake Control Module																																																											
F	2015	SS	Chassis	Parking Brake Control Module																																																											
F	2015	SS	Chassis	Power Steering Control Module																																																											
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2015	SS	Chassis	Suspension Control Module																																																											
F	2015	SS	Body	Body Control Module																																																											
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2015	SS	Body	Passenger Presence Module																																																											
F	2015	SS	Body	Instrument Cluster																																																											
F	2015	SS	Body	Head-Up Display Module																																																											
F	2015	SS	Body	Radio Control																																																											
F	2015	SS	Body	HVAC Control																																																											
F	2015	SS	Body	Headlamp Control Module																																																											
F	2015	SS	Body	Trailer Interface Control Module																																																											
F	2015	SS	Body	Radio																																																											
F	2015	SS	Body	Telematics Communication Interface Control Module																																																											
F	2015	SS	Body	HVAC Control Module																																																											
F	2015	SS	Body	Seat Memory Control Module - Driver																																																											
F	2015	SS	Body	Keyless Entry Control Module																																																											
F	2015	SS	Body	Right Side Object Detection Control Module																																																											
F	2015	SS	Body	Left Side Object Detection Control Module																																																											
F	2015	SS	Body	Parking Assist Control Module																																																											
F	2015	SS	Body	Frontview Camera Module																																																											
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																											
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																											
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																											
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																											
F	2016	Camaro	Powertrain	Transmission Control Module																																																											
F	2016	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2016	Camaro	Chassis	Parking Brake Control Module																																																											
F	2016	Camaro	Chassis	Power Steering Control Module																																																											
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2016	Camaro	Chassis	Suspension Control Module																																																											
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2016	Camaro	Body	Serial Data Gateway Module																																																											
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2016	Camaro	Body	Passenger Presence Module																																																											
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																											
F	2016	Camaro	Body	Head-Up Display Module																																																											
F	2016	Camaro	Body	Auxiliary Gage Module																																																											
F	2016	Camaro	Body	Radio Controls																																																											
F	2016	Camaro	Body	HVAC Controls																																																											
F	2016	Camaro	Body	Vehicle Performance Data Recorder																																																											
F	2016	Camaro	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
F	2016	Camaro	Body	Amplifier																																																										
F	2016	Camaro	Body	Media Disc Player																																																										
F	2016	Camaro	Body	Human Machine Interface Control Module																																																										
F	2016	Camaro	Body	Navigation Control Module																																																										
F	2016	Camaro	Body	Mobile Telephone Control Module																																																										
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																										
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)																																																										
F	2016	Camaro	Body	Seat Memory Control Module - Driver																																																										
F	2016	Camaro	Body	Folding Top Control Module																																																										
F	2016	Camaro	Body	Keyless Entry Control Module																																																										
F	2016	Camaro	Body	Right Side Object Detection Control Module																																																										
F	2016	Camaro	Body	Left Side Object Detection Control Module																																																										
F	2016	Camaro	Body	Parking Assist Control Module																																																										
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2016	SS	Powertrain	Fuel Injector Control Module																																																										
F	2016	SS	Chassis	Electronic Brake Control Module																																																										
F	2016	SS	Chassis	Parking Brake Control Module																																																										
F	2016	SS	Chassis	Power Steering Control Module																																																										
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2016	SS	Chassis	Suspension Control Module																																																										
F	2016	SS	Body	Body Control Module																																																										
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2016	SS	Body	Passenger Presence Module																																																										
F	2016	SS	Body	Instrument Cluster																																																										
F	2016	SS	Body	Head-Up Display Module																																																										
F	2016	SS	Body	Radio Control																																																										
F	2016	SS	Body	HVAC Control																																																										
F	2016	SS	Body	Trailer Interface Control Module																																																										
F	2016	SS	Body	Radio																																																										
F	2016	SS	Body	Telematics Communication Interface Control Module																																																										
F	2016	SS	Body	HVAC Control Module																																																										
F	2016	SS	Body	Seat Memory Control Module - Driver																																																										
F	2016	SS	Body	Keyless Entry Control Module																																																										
F	2016	SS	Body	Right Side Object Detection Control Module																																																										
F	2016	SS	Body	Left Side Object Detection Control Module																																																										
F	2016	SS	Body	Parking Assist Control Module																																																										
F	2016	SS	Body	Frontview Camera Module																																																										
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																										
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
G	2016	Malibu	Powertrain	Fuel Injector Control Module																																																										
G	2016	Malibu	Powertrain	Chassis Control Module																																																										
G	2016	Malibu	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2016	Malibu	Chassis	Parking Brake Control Module																																																										
G	2016	Malibu	Chassis	Power Steering Control Module																																																										
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2016	Malibu	Body	Passenger Presence Module																																																										
G	2016	Malibu	Body	Instrument Cluster																																																										
G	2016	Malibu	Body	Headlamp Control Module																																																										
G	2016	Malibu	Body	Radio																																																										
G	2016	Malibu	Body	Digital Radio Receiver Control Module																																																										
G	2016	Malibu	Body	Multimedia Player Interface Module																																																										
G	2016	Malibu	Body	Mobile Telephone Control Module																																																										
G	2016	Malibu	Body	Telematics Communication Interface Control Module																																																										
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
G	2016	Malibu	Body	Seat Memory Control Module																																																										
G	2016	Malibu	Body	Front Seat Heating Control Module																																																										
G	2016	Malibu	Body	Rear Seat Heating Control Module																																																										
G	2016	Malibu	Body	Keyless Entry Control Module																																																										
G	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
G	2016	Malibu	Body	Parking Assist Control Module																																																										
G	2016	Malibu	Body	Frontview Camera Module																																																										
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
H	2010	Sail	Powertrain	Transmission Control Module																																																										
H	2010	Sail	Chassis	Electronic Brake Control Module																																																										
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
H	2011	Sail	Powertrain	Transmission Control Module																																																										
H	2011	Sail	Chassis	Electronic Brake Control Module																																																										
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	Transmission Control Module																																																										
H	2012	Sail	Chassis	Electronic Brake Control Module																																																										
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	Transmission Control Module																																																										
H	2013	Sail	Chassis	Electronic Brake Control Module																																																										
H	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	Transmission Control Module																																																										
H	2014	Sail	Chassis	Electronic Brake Control Module																																																										
H	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																										
H	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																										
H	2015	Sail	Chassis	Electronic Brake Control Module																																																										
H	2015	Sail	Chassis	Power Steering Control Module																																																										
H	2015	Sail	Body	Body Control Module																																																									
H	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Sail	Body	Radio/HVAC Control																																																										
H	2015	Sail	Body	HVAC Control Module																																																										
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
H	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																										
H	2016	Sail	Chassis	Electronic Brake Control Module																																																										
H	2016	Sail	Chassis	Power Steering Control Module																																																										
H	2016	Sail	Body	Body Control Module																																																									
H	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Sail	Body	Radio/HVAC Control																																																										
H	2016	Sail	Body	Radio																																																										
H	2016	Sail	Body	HVAC Control Module																																																										
J	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
J	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
J	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
J	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
J	2004	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
J	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
J	2004	Optra	Body	Remote Function Actuation																																																										
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel																																																										
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel Transmission Control Module																																																										
J	2004	Cavalier	Chassis	Anti-lock Brake System																																																										
J	2004	Cavalier	Body	Body Control Module																																																										
J	2004	Cavalier	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2004	Cavalier	Body	Instrument Panel Cluster																																																											
J	2004	Cavalier	Body	Radio																																																											
J	2004	Cavalier	Body	Supplemental Inflatable Restraint																																																											
J	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																											
J	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
J	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																											
J	2005	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																											
J	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																											
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																											
J	2005	Optra	Body	Remote Function Actuation																																																											
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																											
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																											
J	2005	Cavalier	Chassis	Anti-lock Brake System																																																											
J	2005	Cavalier	Body	Body Control Module																																																											
J	2005	Cavalier	Body	Digital Radio Receiver																																																											
J	2005	Cavalier	Body	Instrument Panel Cluster																																																											
J	2005	Cavalier	Body	Radio																																																											
J	2005	Cavalier	Body	Supplemental Inflatable Restraint																																																											
J	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																											
J	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
J	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																											
J	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2006	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																											
J	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2006	ALL	Body	Remote Function Actuation																																																											
J	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
J	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																											
J	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
J	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																					
J	2007	ALL	Powertrain	4 Speed Automatic																																																											
J	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2007	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																									
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																											
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																											
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																											
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																											
J	2007	ALL	Chassis	Tire Pressure Monitor																																																											
J	2007	ALL	Body	Remote Function Actuation																																																											
J	2007	ALL	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
J	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
J	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																						
J	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module					V																																																						
J	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																											
J	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2008	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																									
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2008	ALL	Chassis	Tire Pressure Monitor																																																											
J	2008	ALL	Body	Remote Function Actuation																																																											
J	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
J	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
J	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
J	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																						
J	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																											
J	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2009	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																									
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2009	ALL	Chassis	Tire Pressure Monitor																																																											
J	2009	ALL	Body	Remote Function Actuation																																																											
J	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																							
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																							
J	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																											
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																											
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																											
J	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																											
J	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																											
J	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																											
J	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																											
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																											
J	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																											
J	2010	Cruze	Chassis	Electronic Brake Control Module																																																											
J	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2010	Cruze	Body	Body Control Module																																																											
J	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2010	Cruze	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2010	Cruze	Body	Instrument Cluster																																																										
J	2010	Cruze	Body	Trailer Interface Control Module																																																											
J	2010	Cruze	Body	Radio																																																										
J	2010	Cruze	Body	Multimedia Player Interface Module																																																											
J	2010	Cruze	Body	Mobile Telephone Control Module																																																											
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
J	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
J	2010	Cruze	Body	Keyless Entry Control Module																																																											
J	2010	Cruze	Body	Parking Assist Control Module																																																											
J	2010	Cruze	Body	Steering Column Lock Control Module																																																											
J	2010	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2010	Other	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
J	2010	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2010	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																						
J	2010	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2010	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2010	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2010	Other	Powertrain	Transmission Control Module 5 Speed		V																																																									
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2010	Other	Chassis	Tire Pressure Monitor																																																											
J	2010	Other	Body	Remote Function Actuation																																																											
J	2010	Other	Body	Supplemental Inflatable Restraint																																																											
J	2010	Other	Body	Supplemental Inflatable Restraint																																																											
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission	V																																																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission	V																																																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																											
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																											
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V			V																																																							
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V			V																																																							
J	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																											
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																											
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission	V			V																																																							
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission	V			V																																																							
J	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																											
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																							
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																							
J	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																											
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																											
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission	V			V																																																							
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission	V			V																																																							
J	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																																																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																																																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
J	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																											
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																											
J	2011	Cruze	Chassis	Electronic Brake Control Module																																																											
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2011	Cruze	Body	Body Control Module																																																											
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2011	Cruze	Body	Passenger Presence Module																																																											
J	2011	Cruze	Body	Instrument Cluster																																																											
J	2011	Cruze	Body	Trailer Interface Control Module																																																											
J	2011	Cruze	Body	Radio																																																											
J	2011	Cruze	Body	Multimedia Player Interface Module																																																											
J	2011	Cruze	Body	Mobile Telephone Control Module																																																											
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
J	2011	Cruze	Body	Keyless Entry Control Module																																																											
J	2011	Cruze	Body	Parking Assist Control Module																																																											
J	2011	Cruze	Body	Steering Column Lock Control Module																																																											
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																						
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2011	Other	Powertrain	Transmission Control Module 5 Speed		V																																																									
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2011	Other	Chassis	Tire Pressure Monitor																																																											
J	2011	Other	Body	Remote Function Actuation																																																											
J	2011	Other	Body	Supplemental Inflatable Restraint																																																											
J	2011	Other	Body	Supplemental Inflatable Restraint																																																											
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																											
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2012	Aveo	Powertrain	Fuel Pump Control Module																																																												
J	2012	Aveo	Powertrain	Fuel Injector Control Module																																																												
J	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Aveo	Chassis	Electric Power Steering Control Module																																																												
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Aveo	Body	Body Control Module Hatchback																																																												
J	2012	Aveo	Body	Body Control Module Sedan																																																												
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2012	Aveo	Body	Passenger Presence Module																																																												
J	2012	Aveo	Body	Instrument Cluster																																																												
J	2012	Aveo	Body	Radio																																																											
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																												
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
J	2012	Aveo	Body	Front Seat Heating Control Module																																																												
J	2012	Aveo	Body	Parking Assist Control Module																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																												
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2012	Cobalt	Chassis	Electronic Brake Control Module																																																												
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																												
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Cobalt	Body	Body Control Module																																																												
J	2012	Cobalt	Body	Passenger Presence Module																																																												
J	2012	Cobalt	Body	Instrument Cluster																																																												
J	2012	Cobalt	Body	Radio																																																											
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																												
J	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																												
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
J	2012	Cobalt	Body	Front Seat Heating Control Module																																																											
J	2012	Cobalt	Body	Parking Assist Control Module																																																											
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission	V																																																									
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission	V																																																									
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																											
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																											
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V			V																																																							
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V			V																																																							
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																											
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																											
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission	V			V																																																							
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission	V			V																																																							
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																											
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																							
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																							
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																											
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																											
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission	V			V																																																							
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission	V			V																																																							
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V			V																																																							
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V			V																																																							
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																											
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																											
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																											
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																											
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																											
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																											
J	2012	Cruze	Chassis	Electronic Brake Control Module																																																											
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2012	Cruze	Body	Body Control Module Hatchback																																																											
J	2012	Cruze	Body	Body Control Module Sedan																																																											
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2012	Cruze	Body	Passenger Presence Module																																																											
J	2012	Cruze	Body	Instrument Cluster																																																											
J	2012	Cruze	Body	Trailer Interface Control Module																																																											
J	2012	Cruze	Body	Radio																																																										
J	2012	Cruze	Body	Multimedia Player Interface Module																																																											
J	2012	Cruze	Body	Mobile Telephone Control Module																																																											
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
J	2012	Cruze	Body	Keyless Entry Control Module																																																											
J	2012	Cruze	Body	Parking Assist Control Module																																																											
J	2012	Cruze	Body	Steering Column Lock Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																						
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed		V																																																									
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																											
J	2012	Sonic (First Gen)	Body	Remote Function Actuation																																																											
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																											
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																											
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module Chassis Expansion CAN BUS																																																										
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module High Speed CAN Bus																																																										
J	2012	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																										
J	2012	Sonic (Second Gen)	Body	Body Control Module Sedan																																																										
J	2012	Sonic (Second Gen)	Body	Passenger Presence Module																																																										
J	2012	Sonic (Second Gen)	Body	Instrument Cluster																																																										
J	2012	Sonic (Second Gen)	Body	Radio																																																										
J	2012	Sonic (Second Gen)	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																										
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																										
J	2012	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																										
J	2012	Sonic (Second Gen)	Body	Parking Assist Control Module																																																										
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2013	Aveo	Powertrain	Fuel Pump Control Module																																																										
J	2013	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2013	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Aveo	Chassis	Electric Power Steering Control Module																																																										
J	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Aveo	Body	Body Control Module Hatchback																																																										
J	2013	Aveo	Body	Body Control Module Sedan																																																										
J	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Aveo	Body	Passenger Presence Module																																																										
J	2013	Aveo	Body	Instrument Cluster																																																										
J	2013	Aveo	Body	Radio																																																										
J	2013	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Aveo	Body	Front Seat Heating Control Module																																																										
J	2013	Aveo	Body	Parking Assist Control Module																																																										
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2013	Cobalt	Chassis	Electronic Brake Control Module																																																											
J	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2013	Cobalt	Body	Body Control Module																																																											
J	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2013	Cobalt	Body	Instrument Cluster																																																											
J	2013	Cobalt	Body	Radio																																																										
J	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																											
J	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											
J	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
J	2013	Cobalt	Body	Front Seat Heating Control Module																																																											
J	2013	Cobalt	Body	Parking Assist Control Module																																																											
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V			V																																																							
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V			V																																																							
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																																																										
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																																																										
J	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V			V																																																							
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V			V																																																							
J	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V			V																																																							
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V			V																																																							
J	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																							
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																							
J	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V			V																																																						
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V			V																																																						
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																																																									
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																																																									
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																																																									
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																																																									
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2013	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Cruze	Body	Body Control Module Hatchback																																																										
J	2013	Cruze	Body	Body Control Module Sedan																																																										
J	2013	Cruze	Body	Body Control Module Station Wagon																																																										
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Cruze	Body	Passenger Presence Module																																																										
J	2013	Cruze	Body	Instrument Cluster																																																										
J	2013	Cruze	Body	Trailer Interface Control Module																																																										
J	2013	Cruze	Body	Radio																																																										
J	2013	Cruze	Body	Digital Radio Receiver Control Module																																																										
J	2013	Cruze	Body	Multimedia Player Interface Module																																																										
J	2013	Cruze	Body	Mobile Telephone Control Module																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
J	2013	Cruze	Body	Front Seat Heating Control Module																																																										
J	2013	Cruze	Body	Keyless Entry Control Module																																																										
J	2013	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Body	Steering Column Lock Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																				
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed		V																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2013	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																										
J	2013	Sonic (First Gen)	Body	Remote Function Actuation																																																										
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																										
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																																																									
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																																																									
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																										
J	2013	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																										
J	2013	Sonic (Second Gen)	Body	Body Control Module Sedan																																																										
J	2013	Sonic (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Sonic (Second Gen)	Body	Passenger Presence Module																																																										
J	2013	Sonic (Second Gen)	Body	Instrument Cluster																																																										
J	2013	Sonic (Second Gen)	Body	Radio																																																										
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																										
J	2013	Sonic (Second Gen)	Body	Parking Assist Control Module																																																										
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2013	Spin	Chassis	Electronic Brake Control Module																																																										
J	2013	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Spin	Body	Body Control Module																																																										
J	2013	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Spin	Body	Instrument Cluster																																																										
J	2013	Spin	Body	Radio																																																										
J	2013	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Spin	Body	Parking Assist Control Module																																																										
J	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
J	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	Chassis Control Module																																																										
J	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Aveo	Chassis	Power Steering Control Module																																																										
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Aveo	Body	Body Control Module Hatchback																																																										
J	2014	Aveo	Body	Body Control Module Sedan																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Instrument Cluster																																																										
J	2014	Aveo	Body	Radio																																																										
J	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Aveo	Body	Front Seat Heating Control Module																																																										
J	2014	Aveo	Body	Keyless Entry Control Module																																																										
J	2014	Aveo	Body	Parking Assist Control Module																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2014	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Cobalt	Body	Body Control Module																																																										
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Cobalt	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2014	Cobalt	Body	Radio																																																											
J	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											
J	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
J	2014	Cobalt	Body	Front Seat Heating Control Module																																																											
J	2014	Cobalt	Body	Parking Assist Control Module																																																											
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																																																										
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																																																										
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																																																										
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																																																										
J	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																																																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																																																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																											
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																											
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V			V																																																							
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V			V																																																							
J	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																											
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																											
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V			V																																																							
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V			V																																																							
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																											
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																											
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission	V																																																										
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission	V																																																										
J	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																											
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																							
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																							
J	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																											
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																											
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
J	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V			V																																																							
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V			V																																																							
J	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																											
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																																																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																																																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																											
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																											
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																																																									
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																										
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																										
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																										
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																										
J	2014	Cruze	Powertrain	Fuel Injector Control Module																																																										
J	2014	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Cruze	Chassis	Power Steering Control Module																																																										
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Cruze	Body	Body Control Module Hatchback																																																										
J	2014	Cruze	Body	Body Control Module Sedan																																																										
J	2014	Cruze	Body	Body Control Module Station Wagon																																																										
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Cruze	Body	Passenger Presence Module																																																										
J	2014	Cruze	Body	Instrument Cluster																																																										
J	2014	Cruze	Body	Trailer Interface Control Module																																																										
J	2014	Cruze	Body	Radio																																																										
J	2014	Cruze	Body	Digital Radio Receiver Control Module																																																										
J	2014	Cruze	Body	Multimedia Player Interface Module																																																										
J	2014	Cruze	Body	Mobile Telephone Control Module																																																										
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
J	2014	Cruze	Body	Front Seat Heating Control Module																																																										
J	2014	Cruze	Body	Keyless Entry Control Module																																																										
J	2014	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2014	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2014	Cruze	Body	Parking Assist Control Module																																																										
J	2014	Cruze	Body	Steering Column Lock Control Module																																																										
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2014	Sonic	Powertrain	1.4L LDD Chassis Control Module																																																											
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.4L LUJ Chassis Control Module																																																											
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2014	Sonic	Powertrain	(B) 1.4L LUV Chassis Control Module																																																											
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2014	Sonic	Powertrain	(C) 1.6L LDE Chassis Control Module																																																											
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.6L LED Transmission Control Module																																																											
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2014	Sonic	Powertrain	(H) 1.8L LUW Chassis Control Module																																																											
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2014	Sonic	Powertrain	(G) 1.8L LWE Chassis Control Module																																																											
J	2014	Sonic	Powertrain	Fuel Injector Control Module																																																											
J	2014	Sonic	Chassis	Electronic Brake Control Module																																																											
J	2014	Sonic	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2014	Sonic	Chassis	Power Steering Control Module																																																											
J	2014	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2014	Sonic	Body	Body Control Module Hatchback																																																											
J	2014	Sonic	Body	Body Control Module Sedan																																																											
J	2014	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2014	Sonic	Body	Passenger Presence Module																																																											
J	2014	Sonic	Body	Instrument Cluster																																																											
J	2014	Sonic	Body	Radio																																																											
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2014	Sonic	Body	HVAC Control Module Heater Only (C41)																																																											
J	2014	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2014	Sonic	Body	HVAC Control Module Single Zone (C60)																																																											
J	2014	Sonic	Body	Front Seat Heating Control Module																																																											
J	2014	Sonic	Body	Parking Assist Control Module																																																											
J	2014	Sonic	Body	Frontview Camera Module																																																											
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.5L L2B Transmission Control Module																																																										
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2014	Spin	Chassis	Electronic Brake Control Module																																																										
J	2014	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Spin	Body	Body Control Module																																																										
J	2014	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Spin	Body	Instrument Cluster																																																										
J	2014	Spin	Body	Radio																																																										
J	2014	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Spin	Body	Parking Assist Control Module																																																										
J	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
J	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
J	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2015	Aveo	Powertrain	Chassis Control Module																																																										
J	2015	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2015	Aveo	Chassis	Power Steering Control Module																																																										
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Aveo	Body	Body Control Module Hatchback																																																										
J	2015	Aveo	Body	Body Control Module Sedan																																																										
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Aveo	Body	Instrument Cluster																																																										
J	2015	Aveo	Body	Radio																																																										
J	2015	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Aveo	Body	Front Seat Heating Control Module																																																										
J	2015	Aveo	Body	Keyless Entry Control Module																																																										
J	2015	Aveo	Body	Parking Assist Control Module																																																										
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2015	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Cobalt	Body	Body Control Module																																																										
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Cobalt	Body	Instrument Cluster																																																										
J	2015	Cobalt	Body	Radio																																																										
J	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																										
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2015	Cobalt	Body	Parking Assist Control Module																																																										
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																																																									
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																																																									
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																																																									
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																																																									
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																																																									
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																																																									
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V			V																																																						
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V			V																																																						
J	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V			V																																																						
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V			V																																																						
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission	V																																																									
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission	V																																																									
J	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																						
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																						
J	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V			V																																																						
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V			V																																																						
J	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																																																									
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																																																									
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																										
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																										
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																										
J	2015	Cruze	Powertrain	Fuel Injector Control Module																																																										
J	2015	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2015	Cruze	Chassis	Power Steering Control Module																																																										
J	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Cruze	Body	Body Control Module Hatchback																																																										
J	2015	Cruze	Body	Body Control Module Sedan																																																										
J	2015	Cruze	Body	Body Control Module Station Wagon																																																										
J	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Cruze	Body	Passenger Presence Module																																																										
J	2015	Cruze	Body	Instrument Cluster																																																										
J	2015	Cruze	Body	Trailer Interface Control Module																																																										
J	2015	Cruze	Body	Radio																																																										
J	2015	Cruze	Body	Digital Radio Receiver Control Module																																																										
J	2015	Cruze	Body	Multimedia Player Interface Module																																																										
J	2015	Cruze	Body	Mobile Telephone Control Module																																																										
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
J	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
J	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
J	2015	Cruze	Body	Front Seat Heating Control Module																																																										
J	2015	Cruze	Body	Keyless Entry Control Module																																																										
J	2015	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2015	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2015	Cruze	Body	Parking Assist Control Module																																																										
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2015	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																											
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.6L LED Transmission Control Module																																																												
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																																																											
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																																																											
J	2015	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2015	Sonic	Powertrain	Chassis Control Module																																																													
J	2015	Sonic	Powertrain	Fuel Injector Control Module																																																												
J	2015	Sonic	Chassis	Electronic Brake Control Module																																																												
J	2015	Sonic	Chassis	Power Steering Control Module																																																												
J	2015	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2015	Sonic	Body	Body Control Module Hatchback																																																												
J	2015	Sonic	Body	Body Control Module Sedan																																																												
J	2015	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2015	Sonic	Body	Passenger Presence Module																																																												
J	2015	Sonic	Body	Instrument Cluster																																																												
J	2015	Sonic	Body	Radio																																																											
J	2015	Sonic	Body	Telematics Communication Interface Control Module																																																												
J	2015	Sonic	Body	HVAC Control Module Heater Only (C41)																																																												
J	2015	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2015	Sonic	Body	HVAC Control Module Single Zone (C60)																																																												
J	2015	Sonic	Body	Front Seat Heating Control Module																																																												
J	2015	Sonic	Body	Parking Assist Control Module																																																												
J	2015	Sonic	Body	Frontview Camera Module																																																												
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																												
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																												
J	2015	Spin	Powertrain	1.5L L2B Transmission Control Module																																																												
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2015	Spin	Chassis	Electronic Brake Control Module																																																											
J	2015	Spin	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2015	Spin	Body	Body Control Module																																																											
J	2015	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2015	Spin	Body	Instrument Cluster																																																											
J	2015	Spin	Body	Radio																																																											
J	2015	Spin	Body	Telematics Communication Interface Control Module																																																											
J	2015	Spin	Body	HVAC Control Module Heater Only (C41)																																																											
J	2015	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2015	Spin	Body	HVAC Control Module Single Zone (C60)																																																											
J	2015	Spin	Body	Front Seat Heating Control Module																																																											
J	2015	Spin	Body	Parking Assist Control Module																																																											
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																											
J	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																											
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																											
J	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																											
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																											
J	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																											
J	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2016	Aveo	Powertrain	Chassis Control Module																																																											
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
J	2016	Aveo	Chassis	Power Steering Control Module																																																											
J	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Aveo	Body	Body Control Module Hatchback																																																											
J	2016	Aveo	Body	Body Control Module Sedan																																																											
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Aveo	Body	Instrument Cluster																																																											
J	2016	Aveo	Body	Radio																																																											
J	2016	Aveo	Body	Telematics Communication Interface Control Module																																																											
J	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
J	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Aveo	Body	Front Seat Heating Control Module																																																											
J	2016	Aveo	Body	Parking Assist Control Module																																																											
J	2016	Aveo	Body	Keyless Entry Control Module																																																											
J	2016	Aveo	Body	Frontview Camera Module																																																											
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2016	Cobalt	Chassis	Electronic Brake Control Module																																																											
J	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Cobalt	Body	Body Control Module																																																											
J	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Cobalt	Body	Instrument Cluster																																																											
J	2016	Cobalt	Body	Radio Other																																																											
J	2016	Cobalt	Body	Radio (IOB)																																																											
J	2016	Cobalt	Body	Radio (UF7)																																																											
J	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											
J	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Cobalt	Body	Front Seat Heating Control Module																																																											
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																																																										
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																																																										
J	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																																																										
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																																																										
J	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V			V																																																							
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V			V																																																							

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																											
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																											
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V			V																																																							
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V			V																																																							
J	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																											
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																											
J	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																											
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																							
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																							
J	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
J	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V			V																																																							
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V			V																																																							
J	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																											
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																																																										
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																																																										
J	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																																																										
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																																																										
J	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
J	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																											
J	2016	Cruze	Powertrain	Fuel Injector Control Module																																																											
J	2016	Cruze	Powertrain	Chassis Control Module																																																											
J	2016	Cruze	Chassis	Electronic Brake Control Module																																																											
J	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2016	Cruze	Chassis	Power Steering Control Module																																																											
J	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Cruze	Body	Body Control Module Hatchback																																																											
J	2016	Cruze	Body	Body Control Module Sedan																																																											
J	2016	Cruze	Body	Body Control Module Station Wagon																																																											
J	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Cruze	Body	Passenger Presence Module																																																											
J	2016	Cruze	Body	Instrument Cluster																																																											
J	2016	Cruze	Body	Trailer Interface Control Module																																																											
J	2016	Cruze	Body	Radio Other																																																										
J	2016	Cruze	Body	Radio (UF7)																																																											
J	2016	Cruze	Body	Multimedia Player Interface Module																																																											
J	2016	Cruze	Body	Mobile Telephone Control Module																																																											
J	2016	Cruze	Body	Telematics Communication Interface Control Module																																																											
J	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
J	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																											
J	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																											
J	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																											
J	2016	Cruze	Body	Front Seat Heating Control Module																																																											
J	2016	Cruze	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2016	Cruze	Body	Right Side Object Detection Control Module																																																											
J	2016	Cruze	Body	Left Side Object Detection Control Module																																																											
J	2016	Cruze	Body	Parking Assist Control Module																																																											
J	2016	Cruze	Body	Steering Column Lock Control Module																																																											
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																											
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module																																																											
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																																																										
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																																																										
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2016	Sonic	Powertrain	Chassis Control Module																																																											
J	2016	Sonic	Powertrain	Fuel Injector Control Module																																																											
J	2016	Sonic	Chassis	Electronic Brake Control Module																																																											
J	2016	Sonic	Chassis	Power Steering Control Module																																																											
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Sonic	Body	Body Control Module Hatchback																																																											
J	2016	Sonic	Body	Body Control Module Sedan																																																											
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Sonic	Body	Passenger Presence Module																																																											
J	2016	Sonic	Body	Instrument Cluster																																																											
J	2016	Sonic	Body	Radio Other																																																										
J	2016	Sonic	Body	Radio (UF7)																																																										
J	2016	Sonic	Body	Radio (UH7)																																																										
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Sonic	Body	Front Seat Heating Control Module																																																												
J	2016	Sonic	Body	Parking Assist Control Module																																																												
J	2016	Sonic	Body	Frontview Camera Module																																																												
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module																																																												
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module																																																												
J	2016	Spin	Chassis	Electronic Brake Control Module																																																												
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Spin	Body	Body Control Module																																																												
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Spin	Body	Instrument Cluster																																																												
J	2016	Spin	Body	Radio																																																												
J	2016	Spin	Body	Telematics Communication Interface Control Module																																																												
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)																																																												
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)																																																												
J	2016	Spin	Body	Front Seat Heating Control Module																																																												
J	2016	Spin	Body	Parking Assist Control Module																																																												
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																												
K	2006	ALL	Powertrain	Transmission Control Module																																																												
K	2006	ALL	Chassis	Electronic Brake Control Module																																																												
K	2006	ALL	Body	Remote Function Actuation																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																												
K	2007	ALL	Powertrain	Transmission Control Module																																																												
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module																																																												
K	2007	ALL	Chassis	Teves Electronic Brake Control Module																																																												
K	2007	ALL	Body	Remote Function Actuation																																																												
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																												
K	2008	ALL	Powertrain	Transmission Control Module																																																												
K	2008	ALL	Chassis	Electronic Brake Control Module																																																												
K	2008	ALL	Body	Remote Function Actuation																																																												
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2009	ALL	Powertrain	Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2009	ALL	Chassis	Electronic Brake Control Module																																																										
K	2009	ALL	Body	Remote Function Actuation																																																											
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2010	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2010	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																											
K	2010	ALL	Powertrain	Transmission Control Module																																																												
K	2010	ALL	Chassis	Electronic Brake Control Module																																																												
K	2010	ALL	Body	Remote Function Actuation																																																												
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2011	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2011	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2011	ALL	Powertrain	Transmission Control Module																																																												
K	2011	ALL	Chassis	Electronic Brake Control Module																																																												
K	2011	ALL	Body	Remote Function Actuation																																																												
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2012	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2012	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2012	ALL	Powertrain	Transmission Control Module																																																												
K	2012	ALL	Chassis	Electronic Brake Control Module																																																												
K	2012	ALL	Body	Remote Function Actuation																																																												
K	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2013	Onix	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2013	Onix	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																												
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																												
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																												
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																												
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																												
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																												
K	2013	Onix	Powertrain	Transmission Control Module																																																												
K	2013	Onix	Powertrain	Transmission Control Module																																																												
K	2013	Onix	Chassis	Electronic Brake Control Module																																																												
K	2013	Onix	Chassis	Electronic Brake Control Module																																																												
K	2013	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2013	Onix	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2013	Onix	Body	Body Control Module																																																											
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2013	Onix	Body	Instrument Cluster																																																												
K	2013	Onix	Body	Radio																																																												
K	2013	Onix	Body	Parking Assist Control Module																																																												
K	2013	Onix	Body	Remote Function Actuation																																																												
K	2013	Prisma	Powertrain	Engine Control Module																																																												
K	2013	Prisma	Powertrain	Transmission Control Module																																																												
K	2013	Prisma	Chassis	Electronic Brake Control Module																																																												
K	2013	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2013	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2013	Prisma	Body	Body Control Module																																																												
K	2013	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2013	Prisma	Body	Instrument Cluster																																																												
K	2013	Prisma	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2013	Prisma	Body	Parking Assist Control Module																																																										
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2014	Onix	Chassis	Electronic Brake Control Module																																																										
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Onix	Body	Body Control Module																																																										
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Onix	Body	Instrument Cluster																																																										
K	2014	Onix	Body	Radio																																																										
K	2014	Onix	Body	Parking Assist Control Module																																																										
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module																																																										
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2014	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Prisma	Body	Body Control Module																																																										
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Prisma	Body	Instrument Cluster																																																										
K	2014	Prisma	Body	Radio																																																										
K	2014	Prisma	Body	Parking Assist Control Module																																																										
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2015	Onix	Chassis	Electronic Brake Control Module																																																										
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Onix	Body	Body Control Module																																																										
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Onix	Body	Instrument Cluster																																																										
K	2015	Onix	Body	Radio																																																										
K	2015	Onix	Body	Parking Assist Control Module																																																										
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																											
K	2015	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																											
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																											
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																											
K	2015	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																											
K	2015	Prisma	Chassis	Electronic Brake Control Module																																																											
K	2015	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Prisma	Body	Body Control Module																																																											
K	2015	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Prisma	Body	Instrument Cluster																																																											
K	2015	Prisma	Body	Radio																																																											
K	2015	Prisma	Body	Parking Assist Control Module																																																											
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																											
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																											
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																											
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																											
K	2016	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																											
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																											
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																											
K	2016	Onix	Powertrain	1.4L LKK Transmission Control Module																																																											
K	2016	Onix	Chassis	Electronic Brake Control Module																																																											
K	2016	Onix	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2016	Onix	Body	Body Control Module																																																											
K	2016	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2016	Onix	Body	Instrument Cluster																																																											
K	2016	Onix	Body	Radio																																																											
K	2016	Onix	Body	Parking Assist Control Module																																																											
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																											
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																											
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																											
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																											
K	2016	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																											
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																											
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																											
K	2016	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																											
K	2016	Prisma	Chassis	Electronic Brake Control Module																																																											
K	2016	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2016	Prisma	Body	Body Control Module																																																											
K	2016	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2016	Prisma	Body	Instrument Cluster																																																											
K	2016	Prisma	Body	Radio																																																											
K	2016	Prisma	Body	HVAC Control Module																																																											
K	2016	Prisma	Body	Front Seat Heating Control Module																																																											
K	2016	Prisma	Body	Parking Assist Control Module																																																											
L	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
L	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2004	ALL	Powertrain	Transmission Control Module																																																											
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																											
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																											
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2004	ALL	Body	ISU																								V																																		
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2005	ALL	Powertrain	Transmission Control Module																																																										
L	2005	ALL	Chassis	Anti-lock Brake System																																																										
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2005	ALL	Body	ISU																								V																																		
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																										
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																										
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2006	ALL	Body	ISU																								V																																		
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module					V																																																					
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																										
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector																																																										
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																								
L	2007	ALL	Chassis	Electronic Brake Control Module																																																										
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Body	ISU																								V																																		
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module					V																																																					
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																								
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed		V																																																								
L	2008	ALL	Chassis	Electronic Brake Control Module																																																										
L	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2008	ALL	Body	ISU																								V																																		
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module					V																																																					
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed		V																																																								
L	2009	ALL	Chassis	Electronic Brake Control Module																																																										
L	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2009	ALL	Body	ISU																								V																																		
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module					V																																																					
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed		V																																																								
L	2010	ALL	Chassis	Electronic Brake Control Module																																																										
L	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2010	ALL	Body	ISU																								V																																		
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module					V																																																						
L	2011	ALL	Powertrain	Transmission Control Module 6 Speed		V																																																										
L	2011	ALL	Chassis	Electronic Brake Control Module																																																												
L	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
L	2011	ALL	Body	ISU																								V																																				
M	2004	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2004	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2004	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2004	ALL	Chassis	Anti-lock Brake System																																																												
M	2004	ALL	Body	Remote Function Actuation																																																												
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2005	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2005	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2005	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2005	ALL	Chassis	Anti-lock Brake System																																																												
M	2005	ALL	Body	Remote Function Actuation																																																												
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2006	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2006	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2006	ALL	Chassis	Anti-lock Brake System																																																												
M	2006	ALL	Body	Remote Function Actuation																																																												
M	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2007	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2007	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2007	ALL	Chassis	Anti-lock Brake System																																																												
M	2007	ALL	Body	Remote Function Actuation																																																												
M	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2008	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2008	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2008	ALL	Chassis	Anti-lock Brake System																																																												
M	2008	ALL	Body	Remote Function Actuation																																																												
M	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2009	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2009	ALL	Chassis	Anti-lock Brake System																																																												
M	2009	ALL	Body	Remote Function Actuation																																																												
M	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
M	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
M	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
M	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
M	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
M	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
M	2010	Spark	Powertrain	Transmission Control Module																																																												
M	2010	Spark	Chassis	Electronic Brake Control Module																																																												
M	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
M	2010	Spark	Chassis	Electric Power Steering Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
M	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2010	Spark	Body	Passenger Presence Module																																																									
M	2010	Spark	Body	Instrument Cluster																																																									
M	2011	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module	V			V																																																					
M	2011	Caprice	Powertrain	Transmission Control Module		V																																																							
M	2011	Caprice	Powertrain	Fuel Pump Control Module																																																									
M	2011	Caprice	Chassis	Electronic Brake Control Module																																																									
M	2011	Caprice	Body	Body Control Module															V	V		V	V		V		V	V																																	
M	2011	Caprice	Body	HVAC Control Module																													V																													
M	2011	Caprice	Body	Instrument Panel Cluster																																																									
M	2011	Caprice	Body	Passenger Presence System																																									V																
M	2011	Caprice	Body	Radio																																																									
M	2011	Caprice	Body	Remote Control Door Lock Receiver																																																									
M	2011	Caprice	Body	Supplemental Inflatable Restraint																																									V																
M	2011	Caprice	Body	Theft Deterrent Module																																																									
M	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
M	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																									
M	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																									
M	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																									
M	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																									
M	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																									
M	2011	Spark	Powertrain	Transmission Control Module																																																									
M	2011	Spark	Chassis	Electronic Brake Control Module																																																									
M	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
M	2011	Spark	Chassis	Electric Power Steering Control Module																																																									
M	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2011	Spark	Body	Passenger Presence Module																																																									
M	2011	Spark	Body	Instrument Cluster																																																									
M	2012	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module	V			V				V																																																	
M	2012	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module	V			V																																																					
M	2012	Caprice	Powertrain	Transmission Control Module		V																																																							
M	2012	Caprice	Powertrain	Fuel Pump Control Module																																																									
M	2012	Caprice	Chassis	Electronic Brake Control Module																																																									
M	2012	Caprice	Body	Body Control Module															V	V		V	V		V		V	V																																	
M	2012	Caprice	Body	HVAC Control Module																													V																												
M	2012	Caprice	Body	Instrument Panel Cluster																																																									
M	2012	Caprice	Body	Passenger Presence System																																									V																
M	2012	Caprice	Body	Radio																																																									
M	2012	Caprice	Body	Remote Control Door Lock Receiver																																																									
M	2012	Caprice	Body	Supplemental Inflatable Restraint																																																									
M	2012	Caprice	Body	Theft Deterrent Module																																																									
M	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
M	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																									
M	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																									
M	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																									
M	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																									
M	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
M	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
M	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
M	2012	Spark	Powertrain	Transmission Control Module																																																										
M	2012	Spark	Chassis	Electronic Brake Control Module																																																										
M	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2012	Spark	Chassis	Electric Power Steering Control Module																																																										
M	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2012	Spark	Body	Passenger Presence Module																																																										
M	2012	Spark	Body	Instrument Cluster																																																										
M	2013	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module	V			V					V																																																	
M	2013	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module	V			V																																																						
M	2013	Caprice	Powertrain	Transmission Control Module		V																																																								
M	2013	Caprice	Powertrain	Fuel Pump Control Module																																																										
M	2013	Caprice	Chassis	Electronic Brake Control Module																																																										
M	2013	Caprice	Body	Body Control Module														V	V		V	V		V		V	V																																			
M	2013	Caprice	Body	HVAC Control Module																													V																													
M	2013	Caprice	Body	Instrument Panel Cluster																																																										
M	2013	Caprice	Body	Passenger Presence System																																									V																	
M	2013	Caprice	Body	Radio																																																										
M	2013	Caprice	Body	Remote Control Door Lock Receiver																																																										
M	2013	Caprice	Body	Supplemental Inflatable Restraint																																																										
M	2013	Caprice	Body	Theft Deterrent Module																																																										
M	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										
M	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
M	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2013	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2013	Spark	Chassis	Electronic Brake Control Module																																																										
M	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2013	Spark	Chassis	Power Steering Control Module																																																										
M	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2013	Spark	Body	Body Control Module																																																										
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2013	Spark	Body	Passenger Presence Module																																																										
M	2013	Spark	Body	Instrument Cluster																																																										
M	2013	Spark	Body	Radio																																																										
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
M	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
M	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2014	Spark	Chassis	Power Steering Control Module																																																										
M	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2014	Spark	Body	Body Control Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Passenger Presence Module																																																										
M	2014	Spark	Body	Instrument Cluster																																																										
M	2014	Spark	Body	Radio																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark	Body	Keyless Entry Control Module																																																										
M	2014	Spark EV	Powertrain	Engine Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
M	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
M	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2014	Spark EV	Chassis	Power Steering Control Module																																																										
M	2014	Spark EV	Body	Body Control Module																																																										
M	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark EV	Body	Passenger Presence Module																																																										
M	2014	Spark EV	Body	Instrument Cluster																																																										
M	2014	Spark EV	Body	Radio																																																										
M	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
M	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2014	Spark EV	Body	Coolant Heater Control Module																																																											
M	2014	Spark EV	Body	Keyless Entry Control Module																																																											
M	2014	Spark EV	Body	Battery Charger Control Module																																																											
M	2014	Spark EV	Body	DC Charging Control Module																																																											
M	2014	Spark EV	Body	Battery Energy Control Module																																																											
M	2015	Matiz	Powertrain	1.0L LA2 Engine Control Module																																																											
M	2015	Matiz	Chassis	Electronic Brake Control Module																																																											
M	2015	Matiz	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Matiz	Body	Keyless Entry Control Module																																																											
M	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
M	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
M	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
M	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																											
M	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
M	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
M	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
M	2015	Spark	Powertrain	Fuel Injector Control Module																																																											
M	2015	Spark	Chassis	Electronic Brake Control Module																																																											
M	2015	Spark	Chassis	Electronic Brake Control Module																																																											
M	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
M	2015	Spark	Chassis	Power Steering Control Module																																																											
M	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
M	2015	Spark	Body	Body Control Module																																																											
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Spark	Body	Passenger Presence Module																																																											
M	2015	Spark	Body	Instrument Cluster																																																											
M	2015	Spark	Body	Instrument Cluster																																																											
M	2015	Spark	Body	Tire Pressure Indicator Module																																																											
M	2015	Spark	Body	Radio																																																											
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
M	2015	Spark	Body	Keyless Entry Control Module																																																											
M	2015	Spark EV	Powertrain	Engine Control Module																																																											
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
M	2015	Spark EV	Powertrain	Drive Motor Control Module																																																											
M	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
M	2015	Spark EV	Chassis	Electronic Brake Control Module																																																											
M	2015	Spark EV	Chassis	Parking Brake Control Module																																																											
M	2015	Spark EV	Chassis	Power Steering Control Module																																																											
M	2015	Spark EV	Body	Body Control Module																																																											
M	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
M	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Spark EV	Body	Passenger Presence Module																																																											
M	2015	Spark EV	Body	Instrument Cluster																																																											
M	2015	Spark EV	Body	Radio																																																										
M	2015	Spark EV	Body	HVAC Control Module																																																										
M	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2015	Spark EV	Body	Coolant Heater Control Module																																																										
M	2015	Spark EV	Body	Keyless Entry Control Module																																																										
M	2015	Spark EV	Body	Battery Charger Control Module																																																										
M	2015	Spark EV	Body	DC Charging Control Module																																																										
M	2015	Spark EV	Body	Battery Energy Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2016	Spark	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2016	Spark	Chassis	Power Steering Control Module																																																										
M	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2016	Spark	Body	Body Control Module																																																									
M	2016	Spark	Body	Body Control Module																																																									
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Instrument Cluster																																																									
M	2016	Spark	Body	Instrument Cluster																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
M	2016	Spark	Body	Radio																																																										
M	2016	Spark	Body	Telematics Communication Interface Control Module																																																										
M	2016	Spark	Body	Keyless Entry Control Module																																																										
M	2016	Spark EV	Powertrain	Engine Control Module																																																										
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
M	2016	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
M	2016	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2016	Spark EV	Chassis	Power Steering Control Module																																																										
M	2016	Spark EV	Body	Body Control Module																																																										
M	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark EV	Body	Passenger Presence Module																																																										
M	2016	Spark EV	Body	Instrument Cluster																																																										
M	2016	Spark EV	Body	Radio																																																										
M	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
M	2016	Spark EV	Body	HVAC Control Module																																																										
M	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2016	Spark EV	Body	Coolant Heater Control Module																																																										
M	2016	Spark EV	Body	Keyless Entry Control Module																																																										
M	2016	Spark EV	Body	Frontview Camera Module																																																										
M	2016	Spark EV	Body	Battery Charger Control Module																																																										
M	2016	Spark EV	Body	DC Charging Control Module																																																										
M	2016	Spark EV	Body	Battery Energy Control Module																																																										
N	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
N	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2004	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
N	2004	Optra	Body	Remote Function Actuation																																																										
N	2004	Optra	Body	Supplemental Inflatable Restraint																																																										
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
N	2004	Classic	Chassis	Anti-lock Brake System																																																										
N	2004	Classic	Body	Body Control Module																																																										
N	2004	Classic	Body	Radio																																																										
N	2004	Classic	Body	Remote Function Actuation																																																										
N	2004	Classic	Body	Supplemental Inflatable Restraint																																																										
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																										
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Transmission Control Module																																																										
N	2004	Alero (Export)	Chassis	Anti-lock Brake System																																																										
N	2004	Alero (Export)	Body	Body Control Module																																																										
N	2004	Alero (Export)	Body	Instrument Panel Cluster																																																										
N	2004	Alero (Export)	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
N	2004	Alero (Export)	Body	Supplemental Inflatable Restraint																																																										
N	2004	Alero (Export)	Body	Vehicle Theft Deterrent																																																										
N	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
N	2005	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2005	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
N	2005	Optra	Body	Remote Function Actuation																																																										
N	2005	Optra	Body	Supplemental Inflatable Restraint																																																										
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
N	2005	Classic	Chassis	Anti-lock Brake System																																																										
N	2005	Classic	Body	Body Control Module																																																										
N	2005	Classic	Body	Radio																																																										
N	2005	Classic	Body	Remote Function Actuation																																																										
N	2005	Classic	Body	Supplemental Inflatable Restraint																																																										
N	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
N	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2006	ALL	Body	Remote Function Actuation																																																										
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																					
N	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2007	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																								
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																										
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																										
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																										
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																										
N	2007	ALL	Chassis	Tire Pressure Monitor																																																										
N	2007	ALL	Body	Remote Function Actuation																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
N	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
N	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
N	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																												
N	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
N	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
N	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																						
N	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module					V																																																						
N	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
N	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																												
N	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
N	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
N	2008	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																										
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																												
N	2008	ALL	Chassis	Tire Pressure Monitor																																																												
N	2008	ALL	Body	Remote Function Actuation																																																												
N	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
N	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
N	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																												
N	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
N	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
N	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																						
N	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
N	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																												
N	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
N	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
N	2009	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																										
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																												
N	2009	ALL	Chassis	Tire Pressure Monitor																																																												
N	2009	ALL	Body	Remote Function Actuation																																																												
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2010	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
N	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																												
N	2010	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
N	2010	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																						
N	2010	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
N	2010	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
N	2010	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
N	2010	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																										
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																												
N	2010	ALL	Chassis	Tire Pressure Monitor																																																												
N	2010	ALL	Body	Remote Function Actuation																																																												
N	2010	ALL	Body	Remote Function Actuation																																																												
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
N	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
N	2011	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2011	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																					
N	2011	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2011	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2011	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																								
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2011	ALL	Chassis	Tire Pressure Monitor																																																										
N	2011	ALL	Body	Remote Function Actuation																																																										
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2012	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2012	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
N	2012	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2012	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																					
N	2012	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2012	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2012	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																								
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2012	ALL	Chassis	Tire Pressure Monitor																																																										
N	2012	ALL	Body	Remote Function Actuation																																																										
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2013	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2013	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
N	2013	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2013	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module					V																																																					
N	2013	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2013	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2013	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																								
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2013	ALL	Chassis	Tire Pressure Monitor																																																										
N	2013	ALL	Body	Remote Function Actuation																																																										
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
N	2014	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
N	2014	Caprice	Powertrain	(2) 6.0L L77 Chassis Control Module																																																										
N	2014	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
N	2014	Caprice	Chassis	Electronic Brake Control Module																																																										
N	2014	Caprice	Chassis	Parking Brake Control Module																																																										
N	2014	Caprice	Chassis	Power Steering Control Module																																																										
N	2014	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2014	Caprice	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
N	2014	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2014	Caprice	Body	Passenger Presence Module																																																												
N	2014	Caprice	Body	Instrument Cluster																																																											
N	2014	Caprice	Body	Radio Controls																																																											
N	2014	Caprice	Body	HVAC Controls																																																											
N	2014	Caprice	Body	Headlamp Control Module																																																											
N	2014	Caprice	Body	Trailer Interface Control Module																																																											
N	2014	Caprice	Body	Radio																																																											
N	2014	Caprice	Body	HVAC Control Module																																																											
N	2014	Caprice	Body	Parking Assist Control Module																																																											
N	2014	Caprice	Body	Frontview Camera Module																																																											
N	2014	Caprice	Body	Steering Column Lock Control Module																																																											
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
N	2015	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																											
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																											
N	2015	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																											
N	2015	Caprice	Powertrain	Fuel Injector Control Module																																																											
N	2015	Caprice	Chassis	Electronic Brake Control Module																																																											
N	2015	Caprice	Chassis	Parking Brake Control Module																																																											
N	2015	Caprice	Chassis	Power Steering Control Module																																																											
N	2015	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2015	Caprice	Chassis	Suspension Control Module																																																											
N	2015	Caprice	Body	Body Control Module																																																											
N	2015	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2015	Caprice	Body	Passenger Presence Module																																																											
N	2015	Caprice	Body	Instrument Cluster																																																											
N	2015	Caprice	Body	Head-Up Display Module																																																											
N	2015	Caprice	Body	Radio Controls																																																											
N	2015	Caprice	Body	HVAC Controls																																																											
N	2015	Caprice	Body	Headlamp Control Module																																																											
N	2015	Caprice	Body	Trailer Interface Control Module																																																											
N	2015	Caprice	Body	Radio																																																											
N	2015	Caprice	Body	Telematics Communication Interface Control Module																																																											
N	2015	Caprice	Body	HVAC Control Module																																																											
N	2015	Caprice	Body	Right Side Object Detection Control Module																																																											
N	2015	Caprice	Body	Left Side Object Detection Control Module																																																											
N	2015	Caprice	Body	Parking Assist Control Module																																																											
N	2015	Caprice	Body	Frontview Camera Module																																																											
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
N	2016	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																											
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																											
N	2016	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																											
N	2016	Caprice	Powertrain	Fuel Injector Control Module																																																											
N	2016	Caprice	Chassis	Electronic Brake Control Module																																																											
N	2016	Caprice	Chassis	Parking Brake Control Module																																																											
N	2016	Caprice	Chassis	Power Steering Control Module																																																											
N	2016	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
N	2016	Caprice	Chassis	Suspension Control Module																																																											
N	2016	Caprice	Body	Body Control Module																																																											
N	2016	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2016	Caprice	Body	Passenger Presence Module																																																											
N	2016	Caprice	Body	Instrument Cluster																																																											
N	2016	Caprice	Body	Head-Up Display Module																																																											
N	2016	Caprice	Body	Radio Controls																																																											
N	2016	Caprice	Body	HVAC Controls																																																											
N	2016	Caprice	Body	Trailer Interface Control Module																																																											
N	2016	Caprice	Body	Radio																																																											
N	2016	Caprice	Body	Telematics Communication Interface Control Module																																																											
N	2016	Caprice	Body	HVAC Control Module																																																											
N	2016	Caprice	Body	Seat Memory Control Module - Driver																																																											
N	2016	Caprice	Body	Right Side Object Detection Control Module																																																											
N	2016	Caprice	Body	Left Side Object Detection Control Module																																																											
N	2016	Caprice	Body	Parking Assist Control Module																																																											
N	2016	Caprice	Body	Frontview Camera Module																																																											
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																							
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																							
P	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																											
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																											
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																											
P	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																											
P	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																											
P	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																											
P	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																											
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																											
P	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																											
P	2010	Cruze	Chassis	Electronic Brake Control Module																																																											
P	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2010	Cruze	Body	Body Control Module																																																											
P	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2010	Cruze	Body	Passenger Presence Module																																																											
P	2010	Cruze	Body	Instrument Cluster																																																											
P	2010	Cruze	Body	Trailer Interface Control Module																																																											
P	2010	Cruze	Body	Radio																																																											
P	2010	Cruze	Body	Multimedia Player Interface Module																																																											
P	2010	Cruze	Body	Mobile Telephone Control Module																																																											
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2010	Cruze	Body	Keyless Entry Control Module																																																											
P	2010	Cruze	Body	Parking Assist Control Module																																																											
P	2010	Cruze	Body	Steering Column Lock Control Module																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission	V																																																										
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission	V																																																										
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V			V																																																						
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V			V																																																						
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																											
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission	V			V																																																							
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission	V			V																																																							
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																											
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																							
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																							
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																											
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission	V			V																																																							
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission	V			V																																																							
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																																																										
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																																																										
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																											
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2011	Cruze	Chassis	Electronic Brake Control Module																																																											
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2011	Cruze	Body	Body Control Module																																																										
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2011	Cruze	Body	Passenger Presence Module																																																											
P	2011	Cruze	Body	Instrument Cluster																																																											
P	2011	Cruze	Body	Trailer Interface Control Module																																																											
P	2011	Cruze	Body	Radio																																																										
P	2011	Cruze	Body	Multimedia Player Interface Module																																																											
P	2011	Cruze	Body	Mobile Telephone Control Module																																																											
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2011	Cruze	Body	Keyless Entry Control Module																																																											
P	2011	Cruze	Body	Parking Assist Control Module																																																											
P	2011	Cruze	Body	Steering Column Lock Control Module																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission	V																																																										
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission	V																																																										
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																											
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V			V																																																							
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V			V																																																							

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
P	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																											
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																											
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission	V			V																																																							
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission	V			V																																																							
P	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																											
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																							
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																							
P	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																											
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																											
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission	V			V																																																							
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission	V			V																																																							
P	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V			V																																																							
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V			V																																																							
P	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																											
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																																																										
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																																																										
P	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
P	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																											
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																											
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																											
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																											
P	2012	Cruze	Chassis	Electronic Brake Control Module																																																											
P	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2012	Cruze	Body	Body Control Module Hatchback																																																											
P	2012	Cruze	Body	Body Control Module Sedan																																																											
P	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2012	Cruze	Body	Passenger Presence Module																																																											
P	2012	Cruze	Body	Instrument Cluster																																																											
P	2012	Cruze	Body	Trailer Interface Control Module																																																											
P	2012	Cruze	Body	Radio																																																											
P	2012	Cruze	Body	Multimedia Player Interface Module																																																											
P	2012	Cruze	Body	Mobile Telephone Control Module																																																											
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2012	Cruze	Body	Keyless Entry Control Module																																																											
P	2012	Cruze	Body	Parking Assist Control Module																																																											
P	2012	Cruze	Body	Steering Column Lock Control Module																																																											
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V			V																																																							
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V			V																																																							
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																																																									
P	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																												
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																												
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V			V																																																								
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V			V																																																								
P	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V			V																																																								
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V			V																																																								
P	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																								
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																								
P	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V			V																																																								
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V			V																																																								
P	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																																																											
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																																																											
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																												
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																												
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																																																											
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																																																											
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																												
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																												
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2013	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2013	Cruze	Body	Body Control Module Hatchback																																																												
P	2013	Cruze	Body	Body Control Module Sedan																																																												
P	2013	Cruze	Body	Body Control Module Station Wagon																																																												
P	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2013	Cruze	Body	Passenger Presence Module																																																												
P	2013	Cruze	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
P	2013	Cruze	Body	Trailer Interface Control Module																																																										
P	2013	Cruze	Body	Radio																																																										
P	2013	Cruze	Body	Digital Radio Receiver Control Module																																																										
P	2013	Cruze	Body	Multimedia Player Interface Module																																																										
P	2013	Cruze	Body	Mobile Telephone Control Module																																																										
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
P	2013	Cruze	Body	Front Seat Heating Control Module																																																										
P	2013	Cruze	Body	Keyless Entry Control Module																																																										
P	2013	Cruze	Body	Right Side Object Detection Control Module																																																										
P	2013	Cruze	Body	Left Side Object Detection Control Module																																																										
P	2013	Cruze	Body	Parking Assist Control Module																																																										
P	2013	Cruze	Body	Steering Column Lock Control Module																																																										
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																																																									
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																																																									
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																																																									
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																																																									
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																																																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																																																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V			V																																																						
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V			V																																																						
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V			V																																																						
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V			V																																																						
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission	V																																																									
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission	V																																																									
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																						
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																						
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V			V																																																							
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V			V																																																							
P	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																																																											
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																																																											
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																													
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																													
P	2014	Cruze	Powertrain	Fuel Injector Control Module																																																													
P	2014	Cruze	Chassis	Electronic Brake Control Module																																																													
P	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																													
P	2014	Cruze	Chassis	Power Steering Control Module																																																													
P	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
P	2014	Cruze	Body	Body Control Module Hatchback																																																													
P	2014	Cruze	Body	Body Control Module Sedan																																																													
P	2014	Cruze	Body	Body Control Module Station Wagon																																																													
P	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
P	2014	Cruze	Body	Passenger Presence Module																																																													
P	2014	Cruze	Body	Instrument Cluster																																																													
P	2014	Cruze	Body	Trailer Interface Control Module																																																													
P	2014	Cruze	Body	Radio																																																													
P	2014	Cruze	Body	Digital Radio Receiver Control Module																																																													
P	2014	Cruze	Body	Multimedia Player Interface Module																																																													
P	2014	Cruze	Body	Mobile Telephone Control Module																																																													
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																													
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																													
P	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																													
P	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																													
P	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																													
P	2014	Cruze	Body	Front Seat Heating Control Module																																																													
P	2014	Cruze	Body	Keyless Entry Control Module																																																													
P	2014	Cruze	Body	Right Side Object Detection Control Module																																																													
P	2014	Cruze	Body	Left Side Object Detection Control Module																																																													
P	2014	Cruze	Body	Parking Assist Control Module																																																													
P	2014	Cruze	Body	Steering Column Lock Control Module																																																													

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																																																									
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																																																									
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																																																									
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																																																									
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																																																									
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																																																									
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V			V																																																						
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V			V																																																						
P	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V			V																																																						
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V			V																																																						
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission	V																																																									
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission	V																																																									
P	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																						
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																						
P	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V			V																																																						
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V			V																																																						
P	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																																																									
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																																																									
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																																																									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																										
P	2015	Cruze	Powertrain	Fuel Injector Control Module																																																										
P	2015	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2015	Cruze	Chassis	Power Steering Control Module																																																										
P	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2015	Cruze	Body	Body Control Module Hatchback																																																										
P	2015	Cruze	Body	Body Control Module Sedan																																																										
P	2015	Cruze	Body	Body Control Module Station Wagon																																																										
P	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2015	Cruze	Body	Passenger Presence Module																																																										
P	2015	Cruze	Body	Instrument Cluster																																																										
P	2015	Cruze	Body	Trailer Interface Control Module																																																										
P	2015	Cruze	Body	Radio																																																										
P	2015	Cruze	Body	Digital Radio Receiver Control Module																																																										
P	2015	Cruze	Body	Multimedia Player Interface Module																																																										
P	2015	Cruze	Body	Mobile Telephone Control Module																																																										
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
P	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
P	2015	Cruze	Body	Front Seat Heating Control Module																																																										
P	2015	Cruze	Body	Keyless Entry Control Module																																																										
P	2015	Cruze	Body	Right Side Object Detection Control Module																																																										
P	2015	Cruze	Body	Left Side Object Detection Control Module																																																										
P	2015	Cruze	Body	Parking Assist Control Module																																																										
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																																																									
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																																																									
P	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																																																									
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																																																									
P	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission	V			V																																																						
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission	V			V																																																						
P	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission	V			V																																																						

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission	V			V																																																					
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																									
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission	V			V																																																					
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission	V			V																																																					
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission	V			V																																																					
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission	V			V																																																					
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission	V																																																								
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission	V																																																								
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission	V																																																								
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission	V																																																								
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2016	Cruze	Powertrain	Fuel Injector Control Module																																																									
P	2016	Cruze	Powertrain	Chassis Control Module																																																									
P	2016	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2016	Cruze	Chassis	Power Steering Control Module																																																									
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2016	Cruze	Body	Body Control Module Hatchback																																																									
P	2016	Cruze	Body	Body Control Module Sedan																																																									
P	2016	Cruze	Body	Body Control Module Station Wagon																																																									
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2016	Cruze	Body	Passenger Presence Module																																																									
P	2016	Cruze	Body	Instrument Cluster																																																									
P	2016	Cruze	Body	Trailer Interface Control Module																																																									
P	2016	Cruze	Body	Radio Other																																																									
P	2016	Cruze	Body	Radio (UF7)																																																									
P	2016	Cruze	Body	Multimedia Player Interface Module																																																									
P	2016	Cruze	Body	Mobile Telephone Control Module																																																									
P	2016	Cruze	Body	Telematics Communication Interface Control Module																																																									
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																									
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																									
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																									
P	2016	Cruze	Body	Front Seat Heating Control Module																																																									
P	2016	Cruze	Body	Keyless Entry Control Module																																																									
P	2016	Cruze	Body	Right Side Object Detection Control Module																																																									
P	2016	Cruze	Body	Left Side Object Detection Control Module																																																									
P	2016	Cruze	Body	Parking Assist Control Module																																																									
P	2016	Cruze	Body	Steering Column Lock Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2011	Volt	Powertrain	Engine Control Module																																																										
R	2011	Volt	Powertrain	Trasmission Control Module																																																											
R	2011	Volt	Powertrain	Fuel Pump Control Module																																																											
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module																																																											
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2011	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2011	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2011	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2011	Volt	Chassis	Electronic Brake Control Module																																																											
R	2011	Volt	Chassis	Parking Brake Control Module																																																											
R	2011	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
R	2011	Volt	Chassis	Power Steering Control Module																																																											
R	2011	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2011	Volt	Body	Body Control Module																																																											
R	2011	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2011	Volt	Body	Passenger Presence Module																																																											
R	2011	Volt	Body	Instrument Cluster																																																											
R	2011	Volt	Body	Radio																																																											
R	2011	Volt	Body	Digital Radio Receiver Control Module																																																											
R	2011	Volt	Body	Mobile Telephone Control Module																																																											
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2011	Volt	Body	Remote Heater and Air Conditioning Control Module																																																											
R	2011	Volt	Body	Electric A/C Compressor Control Module																																																											
R	2011	Volt	Body	Coolant Heater Control Module																																																											
R	2011	Volt	Body	Keyless Entry Control Module																																																											
R	2011	Volt	Body	Parking Assist Control Module																																																											
R	2011	Volt	Body	Steering Column Lock Control Module																																																											
R	2011	Volt	Body	Battery Charger Control Module																																																											
R	2011	Volt	Body	Battery Energy Control Module																																																											
R	2012	Volt	Powertrain	Engine Control Module																																																											
R	2012	Volt	Powertrain	Trasmission Control Module																																																											
R	2012	Volt	Powertrain	Fuel Pump Control Module																																																											
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module																																																											
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2012	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2012	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2012	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2012	Volt	Chassis	Electronic Brake Control Module																																																											
R	2012	Volt	Chassis	Parking Brake Control Module																																																											
R	2012	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
R	2012	Volt	Chassis	Power Steering Control Module																																																											
R	2012	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2012	Volt	Body	Body Control Module																																																											
R	2012	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2012	Volt	Body	Passenger Presence Module																																																											
R	2012	Volt	Body	Instrument Cluster																																																											
R	2012	Volt	Body	Radio																																																											
R	2012	Volt	Body	Digital Radio Receiver Control Module																																																											
R	2012	Volt	Body	Mobile Telephone Control Module																																																											
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 9																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2012	Volt	Body	Remote Heater and Air Conditioning Control Module																																																										
R	2012	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2012	Volt	Body	Coolant Heater Control Module																																																										
R	2012	Volt	Body	Keyless Entry Control Module																																																										
R	2012	Volt	Body	Parking Assist Control Module																																																										
R	2012	Volt	Body	Steering Column Lock Control Module																																																										
R	2012	Volt	Body	Battery Charger Control Module																																																										
R	2012	Volt	Body	Battery Energy Control Module																																																										
R	2013	Volt	Powertrain	Engine Control Module																																																										
R	2013	Volt	Powertrain	Trasmission Control Module																																																										
R	2013	Volt	Powertrain	Fuel Pump Control Module																																																										
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2013	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2013	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2013	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2013	Volt	Chassis	Electronic Brake Control Module																																																										
R	2013	Volt	Chassis	Parking Brake Control Module																																																										
R	2013	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2013	Volt	Chassis	Power Steering Control Module																																																										
R	2013	Volt	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2013	Volt	Body	Body Control Module																																																										
R	2013	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2013	Volt	Body	Passenger Presence Module																																																										
R	2013	Volt	Body	Instrument Cluster																																																										
R	2013	Volt	Body	Radio																																																										
R	2013	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2013	Volt	Body	Multimedia Player Interface Module																																																										
R	2013	Volt	Body	Mobile Telephone Control Module																																																										
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2013	Volt	Body	HVAC Control Module																																																										
R	2013	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2013	Volt	Body	Coolant Heater Control Module																																																										
R	2013	Volt	Body	Front Seat Heating Control Module																																																										
R	2013	Volt	Body	Keyless Entry Control Module																																																										
R	2013	Volt	Body	Parking Assist Control Module																																																										
R	2013	Volt	Body	Frontview Camera Module																																																										
R	2013	Volt	Body	Steering Column Lock Control Module																																																										
R	2013	Volt	Body	Battery Charger Control Module																																																										
R	2013	Volt	Body	Battery Energy Control Module																																																										
R	2014	Volt	Powertrain	Engine Control Module																																																										
R	2014	Volt	Powertrain	Trasmission Control Module																																																										
R	2014	Volt	Powertrain	Chassis Control Module																																																										
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2014	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2014	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2014	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2014	Volt	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2014	Volt	Chassis	Parking Brake Control Module																																																										
R	2014	Volt	Chassis	Power Steering Control Module																																																											
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2014	Volt	Body	Body Control Module																																																											
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2014	Volt	Body	Passenger Presence Module																																																											
R	2014	Volt	Body	Instrument Cluster																																																											
R	2014	Volt	Body	Radio																																																											
R	2014	Volt	Body	Digital Radio Receiver Control Module																																																											
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2014	Volt	Body	HVAC Control Module																																																											
R	2014	Volt	Body	Electric A/C Compressor Control Module																																																											
R	2014	Volt	Body	Coolant Heater Control Module																																																											
R	2014	Volt	Body	Front Seat Heating Control Module																																																											
R	2014	Volt	Body	Keyless Entry Control Module																																																											
R	2014	Volt	Body	Parking Assist Control Module																																																											
R	2014	Volt	Body	Frontview Camera Module																																																											
R	2014	Volt	Body	Steering Column Lock Control Module																																																											
R	2014	Volt	Body	Battery Charger Control Module																																																											
R	2014	Volt	Body	Battery Energy Control Module																																																											
R	2015	Volt	Powertrain	Engine Control Module																																																											
R	2015	Volt	Powertrain	Trasmission Control Module																																																											
R	2015	Volt	Powertrain	Chassis Control Module																																																											
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module																																																											
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2015	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2015	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2015	Volt	Chassis	Electronic Brake Control Module																																																											
R	2015	Volt	Chassis	Parking Brake Control Module																																																											
R	2015	Volt	Chassis	Power Steering Control Module																																																											
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2015	Volt	Body	Body Control Module																																																											
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2015	Volt	Body	Passenger Presence Module																																																											
R	2015	Volt	Body	Instrument Cluster																																																											
R	2015	Volt	Body	Radio																																																											
R	2015	Volt	Body	Digital Radio Receiver Control Module																																																											
R	2015	Volt	Body	Telematics Communication Interface Control Module																																																											
R	2015	Volt	Body	HVAC Control Module																																																											
R	2015	Volt	Body	Electric A/C Compressor Control Module																																																											
R	2015	Volt	Body	Coolant Heater Control Module																																																											
R	2015	Volt	Body	Front Seat Heating Control Module																																																											
R	2015	Volt	Body	Keyless Entry Control Module																																																											
R	2015	Volt	Body	Parking Assist Control Module																																																											
R	2015	Volt	Body	Frontview Camera Module																																																											
R	2015	Volt	Body	Steering Column Lock Control Module																																																											
R	2015	Volt	Body	Battery Charger Control Module																																																											
R	2015	Volt	Body	Battery Energy Control Module																																																											
R	2016	Volt	Powertrain	Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2016	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2016	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2016	Volt	Chassis	Electronic Brake Control Module																																																										
R	2016	Volt	Chassis	Brake Booster Control Module																																																										
R	2016	Volt	Chassis	Power Steering Control Module																																																										
R	2016	Volt	Body	Body Control Module																																																										
R	2016	Volt	Body	Pedestrian Alert Sound Control Module																																																										
R	2016	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Volt	Body	Passenger Presence Module																																																										
R	2016	Volt	Body	Instrument Cluster																																																										
R	2016	Volt	Body	Radio Controls																																																										
R	2016	Volt	Body	HVAC Controls																																																										
R	2016	Volt	Body	Radio																																																										
R	2016	Volt	Body	Amplifier																																																										
R	2016	Volt	Body	Human Machine Interface Control Module																																																										
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 9.7																																																										
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2016	Volt	Body	HVAC Control Module																																																										
R	2016	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2016	Volt	Body	Keyless Entry Control Module																																																										
R	2016	Volt	Body	Right Side Object Detection Control Module																																																										
R	2016	Volt	Body	Left Side Object Detection Control Module																																																										
R	2016	Volt	Body	Parking Assist Control Module																																																										
R	2016	Volt	Body	Frontview Camera Module																																																										
R	2016	Volt	Body	Steering Column Lock Control Module																																																										
R	2016	Volt	Body	Battery Energy Control Module																																																										
R	2016	Volt	Body	Long Range Radar Sensor Module																																																										
S	2004	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2004	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2004	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2004	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
S	2004	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2004	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
S	2004	Aveo	Powertrain	Transmission Control Module																																																										
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2004	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2004	Aveo	Body	Remote Function Actuation																																																										
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2005	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2005	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2005	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
S	2005	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2005	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
S	2005	Aveo	Powertrain	Transmission Control Module																																																										
S	2005	Aveo	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2005	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2005	Aveo	Body	Remote Function Actuation																																																										
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2006	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
S	2006	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
S	2006	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
S	2006	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2006	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2006	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2006	Aveo	Body	Remote Function Actuation																																																										
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2007	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
S	2007	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
S	2007	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
S	2007	Aveo	Powertrain	Transmission Control Module 4 Speed																																																										
S	2007	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2007	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2007	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2007	Aveo	Body	Remote Function Actuation																																																										
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2008	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2008	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
S	2008	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module									V																																																	
S	2008	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2008	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
S	2008	Aveo	Powertrain	Transmission Control Module																																																										
S	2008	Aveo	Powertrain	Transmission Control Module																																																										
S	2008	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2008	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2008	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2008	Aveo	Body	Remote Function Actuation																																																										
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2009	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
S	2009	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module									V																																																	
S	2009	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2009	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module	V			V						V																																																	
S	2009	Aveo	Powertrain	Transmission Control Module																																																												
S	2009	Aveo	Powertrain	Transmission Control Module																																																												
S	2009	Aveo	Powertrain	Other Auto Transmission System																																																												
S	2009	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2009	Aveo	Chassis	Tire Pressure Monitor																																																												
S	2009	Aveo	Body	Supplemental Inflatable Restraint																																																												
S	2009	Aveo	Body	Remote Function Actuation																																																												
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																												
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																												
S	2010	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
S	2010	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
S	2010	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module									V																																																		
S	2010	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
S	2010	Aveo	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																												
S	2010	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module	V			V						V																																																		
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2010	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2010	Aveo	Chassis	Tire Pressure Monitor																																																												
S	2010	Aveo	Body	Supplemental Inflatable Restraint																																																												
S	2010	Aveo	Body	Remote Function Actuation																																																												
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																												
S	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																												
S	2010	Sail	Powertrain	Transmission Control Module																																																												
S	2010	Sail	Chassis	Electronic Brake Control Module																																																												
S	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																												
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																												
S	2011	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
S	2011	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
S	2011	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module									V																																																		
S	2011	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
S	2011	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module	V			V						V																																																		
S	2011	Aveo	Powertrain	(G)1.6L L4 LXV Engine Control Module	V			V						V																																																		
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2011	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2011	Aveo	Chassis	Tire Pressure Monitor																																																												
S	2011	Aveo	Body	Supplemental Inflatable Restraint																																																												
S	2011	Aveo	Body	Remote Function Actuation																																																												
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																												
S	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																												
S	2011	Sail	Powertrain	Transmission Control Module																																																												
S	2011	Sail	Chassis	Electronic Brake Control Module																																																												
S	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																											
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																											
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																											
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
S	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
S	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module									V																																																	
S	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
S	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																											
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																											
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
S	2012	Aveo	Powertrain	Fuel Pump Control Module																																																											
S	2012	Aveo	Powertrain	Fuel Injector Control Module																																																											
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2012	Aveo	Chassis	Electric Power Steering Control Module																																																											
S	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2012	Aveo	Chassis	Tire Pressure Monitor																																																											
S	2012	Aveo	Body	Body Control Module Hatchback																																																											
S	2012	Aveo	Body	Body Control Module Sedan																																																											
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2012	Aveo	Body	Passenger Presence Module																																																											
S	2012	Aveo	Body	Instrument Cluster																																																											
S	2012	Aveo	Body	Radio																																																										
S	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																											
S	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
S	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
S	2012	Aveo	Body	Front Seat Heating Control Module																																																											
S	2012	Aveo	Body	Remote Function Actuation																																																											
S	2012	Aveo	Body	Parking Assist Control Module																																																											
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																										
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																										
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2012	Sail	Powertrain	Transmission Control Module																																																										
S	2012	Sail	Chassis	Electronic Brake Control Module																																																										
S	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module									V																																																	
S	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
S	2013	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2013	Aveo	Powertrain	Fuel Pump Control Module																																																										
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2013	Aveo	Chassis	Electric Power Steering Control Module																																																										
S	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2013	Aveo	Body	Body Control Module Hatchback																																																										
S	2013	Aveo	Body	Body Control Module Sedan																																																										
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Aveo	Body	Passenger Presence Module																																																										
S	2013	Aveo	Body	Instrument Cluster																																																										
S	2013	Aveo	Body	Radio																																																										
S	2013	Aveo	Body	Telematics Communication Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2013	Aveo	Body	Front Seat Heating Control Module																																																										
S	2013	Aveo	Body	Remote Function Actuation																																																										
S	2013	Aveo	Body	Parking Assist Control Module																																																										
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2013	Sail	Powertrain	Transmission Control Module																																																										
S	2013	Sail	Chassis	Electronic Brake Control Module																																																										
S	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
S	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
S	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
S	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
S	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
S	2014	Aveo	Powertrain	Chassis Control Module																																																										
S	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2014	Aveo	Chassis	Power Steering Control Module																																																										
S	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2014	Aveo	Body	Body Control Module Hatchback																																																										
S	2014	Aveo	Body	Body Control Module Sedan																																																										
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Aveo	Body	Instrument Cluster																																																										
S	2014	Aveo	Body	Radio																																																										
S	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
S	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2014	Aveo	Body	Front Seat Heating Control Module																																																										
S	2014	Aveo	Body	Keyless Entry Control Module																																																										
S	2014	Aveo	Body	Parking Assist Control Module																																																										
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2014	Sail	Powertrain	Transmission Control Module																																																										
S	2014	Sail	Chassis	Electronic Brake Control Module																																																										
S	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
S	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																											
S	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																											
S	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																											
S	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
S	2015	Aveo	Powertrain	Chassis Control Module																																																												
S	2015	Aveo	Powertrain	Fuel Injector Control Module																																																												
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2015	Aveo	Chassis	Power Steering Control Module																																																												
S	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2015	Aveo	Body	Body Control Module Hatchback																																																												
S	2015	Aveo	Body	Body Control Module Sedan																																																												
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2015	Aveo	Body	Instrument Cluster																																																											
S	2015	Aveo	Body	Radio																																																											
S	2015	Aveo	Body	Telematics Communication Interface Control Module																																																											
S	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
S	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
S	2015	Aveo	Body	Front Seat Heating Control Module																																																											
S	2015	Aveo	Body	Keyless Entry Control Module																																																											
S	2015	Aveo	Body	Parking Assist Control Module																																																											
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
S	2015	Sail	Powertrain	Transmission Control Module																																																											
S	2015	Sail	Chassis	Electronic Brake Control Module																																																											
S	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
S	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
S	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
S	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
S	2016	Aveo	Powertrain	Chassis Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Power Steering Control Module																																																										
S	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	Aveo	Body	Body Control Module Hatchback																																																										
S	2016	Aveo	Body	Body Control Module Sedan																																																										
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Body	Instrument Cluster																																																										
S	2016	Aveo	Body	Radio																																																										
S	2016	Aveo	Body	Telematics Communication Interface Control Module																																																										
S	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2016	Aveo	Body	Front Seat Heating Control Module																																																										
S	2016	Aveo	Body	Parking Assist Control Module																																																										
S	2016	Aveo	Body	Keyless Entry Control Module																																																										
S	2016	Aveo	Body	Frontview Camera Module																																																										
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																										
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2016	Sail	Powertrain	Transmission Control Module																																																										
S	2016	Sail	Chassis	Electronic Brake Control Module																																																										
S	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2004	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2004	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2004	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
T	2004	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2004	ALL	Powertrain	Transmission Control Module																																																										
T	2004	ALL	Chassis	Electronic Brake Control Module																																																										
T	2004	ALL	Chassis	Electronic Brake Control Module																																																										
T	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2004	ALL	Body	Remote Function Actuation																																																										
T	2005	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2005	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2005	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
T	2005	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2005	ALL	Powertrain	Transmission Control Module																																																										
T	2005	ALL	Chassis	Electronic Brake Control Module																																																										
T	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2005	ALL	Body	Remote Function Actuation																																																										
T	2006	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
T	2006	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
T	2006	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
T	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2006	ALL	Chassis	Electronic Brake Control Module																																																										
T	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2006	ALL	Body	Remote Function Actuation																																																										
T	2007	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
T	2007	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
T	2007	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
T	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
T	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2007	ALL	Chassis	Electronic Brake Control Module																																																										
T	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2007	ALL	Body	Remote Function Actuation																																																										
T	2008	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
T	2008	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2008	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module									V																																																	
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																											
T	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
T	2008	ALL	Powertrain	Transmission Control Module																																																											
T	2008	ALL	Powertrain	Transmission Control Module																																																											
T	2008	ALL	Chassis	Electronic Brake Control Module																																																											
T	2008	ALL	Chassis	Tire Pressure Monitor																																																											
T	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2008	ALL	Body	Remote Function Actuation																																																											
T	2008	ALL	Body	Passenger Presence System																																									V																	
T	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																											
T	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
T	2009	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module	V			V						V																																																	
T	2009	ALL	Powertrain	Transmission Control Module																																																											
T	2009	ALL	Powertrain	Transmission Control Module																																																											
T	2009	ALL	Chassis	Electronic Brake Control Module																																																											
T	2009	ALL	Chassis	Tire Pressure Monitor																																																											
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2009	ALL	Body	Supplemental Inflatable Restraint																																									V																	
T	2009	ALL	Body	Instrument Panel Cluster																																																					V				
T	2009	ALL	Body	Passenger Presence System																																									V																	
T	2009	ALL	Body	Theft Deterrent Module																																																											
T	2009	ALL	Body	Radio																																																											
T	2009	ALL	Body	Remote Function Actuation																																																											
T	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
T	2010	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module									V																																																		
T	2010	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module	V			V						V																																																	
T	2010	ALL	Powertrain	Transmission Control Module																																																											
T	2010	ALL	Powertrain	Transmission Control Module																																																											
T	2010	ALL	Chassis	Electronic Brake Control Module																																																											
T	2010	ALL	Chassis	Tire Pressure Monitor																																																											
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2010	ALL	Body	Supplemental Inflatable Restraint																																									V																	
T	2010	ALL	Body	Instrument Panel Cluster																																																					V				
T	2010	ALL	Body	Passenger Presence System																																									V																	
T	2010	ALL	Body	Theft Deterrent Module																																																											
T	2010	ALL	Body	Radio																																																											
T	2010	ALL	Body	Remote Function Actuation																																																											
T	2011	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																											
T	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
T	2011	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module									V																																																		
T	2011	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module Argentia																																																											
T	2011	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module	V			V						V																																																	
T	2011	ALL	Powertrain	(G)1.6L L4 LXV Engine Control Module	V			V						V																																																	
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
T	2011	ALL	Chassis	Electronic Brake Control Module																																																											
T	2011	ALL	Chassis	Tire Pressure Monitor																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2011	ALL	Body	Supplemental Inflatable Restraint																																										V																
T	2011	ALL	Body	Instrument Panel Cluster																																																					V			
T	2011	ALL	Body	Passenger Presence System																																										V															
T	2011	ALL	Body	Theft Deterrent Module																																																									
T	2011	ALL	Body	Radio																																																									
T	2011	ALL	Body	Remote Function Actuation																																																									
T	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																									
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
T	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
T	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module									V																																															
T	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
T	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																									
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
T	2012	Aveo	Powertrain	Fuel Injector Control Module																																																									
T	2012	Aveo	Powertrain	Fuel Pump Control Module																																																									
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2012	Aveo	Chassis	Electric Power Steering Control Module																																																									
T	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2012	Aveo	Chassis	Tire Pressure Monitor																																																									
T	2012	Aveo	Body	Body Control Module Hatchback																																																									
T	2012	Aveo	Body	Body Control Module Sedan																																																									
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2012	Aveo	Body	Passenger Presence Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2012	Aveo	Body	Instrument Cluster																																																									
T	2012	Aveo	Body	Radio																																																									
T	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																									
T	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
T	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
T	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
T	2012	Aveo	Body	Front Seat Heating Control Module																																																									
T	2012	Aveo	Body	Remote Function Actuation																																																									
T	2012	Aveo	Body	Parking Assist Control Module																																																									
T	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																									
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
T	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
T	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module									V																																															
T	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
T	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
T	2013	Aveo	Powertrain	Fuel Injector Control Module																																																									
T	2013	Aveo	Powertrain	Fuel Pump Control Module																																																									
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2013	Aveo	Chassis	Electric Power Steering Control Module																																																									
T	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2013	Aveo	Body	Body Control Module Hatchback																																																									
T	2013	Aveo	Body	Body Control Module Sedan																																																									
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2013	Aveo	Body	Passenger Presence Module																																																									
T	2013	Aveo	Body	Instrument Cluster																																																									
T	2013	Aveo	Body	Radio																																																									
T	2013	Aveo	Body	Telematics Communication Interface Control Module																																																									
T	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
T	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
T	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2013	Aveo	Body	Front Seat Heating Control Module																																																										
T	2013	Aveo	Body	Remote Function Actuation																																																										
T	2013	Aveo	Body	Parking Assist Control Module																																																										
T	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
T	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
T	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
T	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
T	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
T	2014	Aveo	Powertrain	Chassis Control Module																																																										
T	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	Aveo	Chassis	Power Steering Control Module																																																										
T	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	Aveo	Body	Body Control Module Hatchback																																																										
T	2014	Aveo	Body	Body Control Module Sedan																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Aveo	Body	Instrument Cluster																																																										
T	2014	Aveo	Body	Radio																																																										
T	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2014	Aveo	Body	Front Seat Heating Control Module																																																										
T	2014	Aveo	Body	Keyless Entry Control Module																																																										
T	2014	Aveo	Body	Parking Assist Control Module																																																										
T	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
T	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
T	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
T	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
T	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
T	2015	Aveo	Powertrain	Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2015	Aveo	Powertrain	Fuel Injector Control Module																																																										
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2015	Aveo	Chassis	Power Steering Control Module																																																										
T	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2015	Aveo	Body	Body Control Module Hatchback																																																										
T	2015	Aveo	Body	Body Control Module Sedan																																																										
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Aveo	Body	Instrument Cluster																																																										
T	2015	Aveo	Body	Radio																																																										
T	2015	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2015	Aveo	Body	Front Seat Heating Control Module																																																										
T	2015	Aveo	Body	Keyless Entry Control Module																																																										
T	2015	Aveo	Body	Parking Assist Control Module																																																										
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
T	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
T	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
T	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
T	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
T	2016	Aveo	Powertrain	Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2016	Aveo	Chassis	Power Steering Control Module																																																											
T	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2016	Aveo	Body	Body Control Module Hatchback																																																											
T	2016	Aveo	Body	Body Control Module Sedan																																																											
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2016	Aveo	Body	Instrument Cluster																																																											
T	2016	Aveo	Body	Radio																																																											
T	2016	Aveo	Body	Telematics Communication Interface Control Module																																																											
T	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
T	2016	Aveo	Body	Front Seat Heating Control Module																																																											
T	2016	Aveo	Body	Parking Assist Control Module																																																											
T	2016	Aveo	Body	Keyless Entry Control Module																																																											
T	2016	Aveo	Body	Frontview Camera Module																																																											
U	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2004	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																											
U	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2004	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																											
U	2004	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
U	2004	ALL	Chassis	Electronic Brake Control Module																																																											
U	2004	ALL	Chassis	Electronic Brake Control Module																																																											
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2004	ALL	Body	Remote Function Actuation																																																											
U	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2005	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																											
U	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2005	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																											
U	2005	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
U	2005	ALL	Chassis	Electronic Brake Control Module																																																											
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2005	ALL	Body	Remote Function Actuation																																																											
U	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2006	ALL	Powertrain	Transmission Control Module																																																											
U	2006	ALL	Chassis	Electronic Brake Control Module																																																											
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2006	ALL	Body	Remote Function Actuation																																																											
U	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2007	ALL	Powertrain	Transmission Control Module																																																											
U	2007	ALL	Chassis	Electronic Brake Control Module																																																											
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
U	2007	ALL	Body	Remote Function Actuation																																																										
U	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
U	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2008	ALL	Powertrain	Transmission Control Module																																																											
U	2008	ALL	Chassis	Electronic Brake Control Module																																																											
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2008	ALL	Body	Remote Function Actuation																																																											
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
U	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																											
U	2010	Sail	Powertrain	Transmission Control Module																																																											
U	2010	Sail	Chassis	Electronic Brake Control Module																																																											
U	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																											
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																											
U	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																											
U	2011	Sail	Powertrain	Transmission Control Module																																																											
U	2011	Sail	Chassis	Electronic Brake Control Module																																																											
U	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																											
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																											
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																											
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																											
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
U	2012	Sail	Powertrain	Transmission Control Module																																																											
U	2012	Sail	Chassis	Electronic Brake Control Module																																																											
U	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
U	2013	Sail	Powertrain	Transmission Control Module																																																											
U	2013	Sail	Chassis	Electronic Brake Control Module																																																											
U	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
U	2014	Sail	Powertrain	Transmission Control Module																																																											
U	2014	Sail	Chassis	Electronic Brake Control Module																																																											
U	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
U	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																											
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
U	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																											
U	2015	Sail	Powertrain	Transmission Control Module																																																											
U	2015	Sail	Chassis	Electronic Brake Control Module																																																											
U	2015	Sail	Chassis	Electronic Brake Control Module																																																											
U	2015	Sail	Chassis	Power Steering Control Module																																																											
U	2015	Sail	Body	Body Control Module																																																											
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2015	Sail	Body	Radio/HVAC Control																																																											
U	2015	Sail	Body	HVAC Control Module																																																											
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
U	2016	Sail	Powertrain	1.2L LMU Transmission Control Module																																																											
U	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																											
U	2016	Sail	Powertrain	1.3L LDV Transmission Control Module																																																											
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
U	2016	Sail	Powertrain	1.4L LCU Transmission Control Module																																																											
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																											
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																											
U	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																											
U	2016	Sail	Chassis	Electronic Brake Control Module																																																											
U	2016	Sail	Chassis	Electronic Brake Control Module																																																											
U	2016	Sail	Chassis	Power Steering Control Module																																																											
U	2016	Sail	Body	Body Control Module																																																											
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2016	Sail	Body	Radio/HVAC Control																																																											
U	2016	Sail	Body	Radio																																																											
U	2016	Sail	Body	HVAC Control Module																																																											
V	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
V	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
V	2004	ALL	Powertrain	Transmission Control Module 4 Speed																																																											
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																											
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																											
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2004	ALL	Body	ISU																								V																																		
V	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
V	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
V	2005	ALL	Powertrain	Transmission Control Module 4 Speed																																																											
V	2005	ALL	Chassis	Electronic Brake Control Module																																																											
V	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2005	ALL	Body	ISU																								V																																		
V	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
V	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
V	2006	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																										
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																										
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2006	ALL	Body	ISU																								V																																		
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																										
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector Control Module																																																										
V	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
V	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module					V																																																					
V	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
V	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
V	2007	ALL	Powertrain	Transmission Control Module 5 Speed		V																																																								
V	2007	ALL	Chassis	Electronic Brake Control Module																																																										
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2007	ALL	Body	ISU																								V																																		
V	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
V	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2008	ALL	Powertrain	Transmission Control Module 6 Speed		V																																																								
V	2008	ALL	Chassis	Electronic Brake Control Module																																																										
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2008	ALL	Body	ISU																								V																																		
V	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
V	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2009	ALL	Powertrain	Transmission Control Module 6 Speed		V																																																								
V	2009	ALL	Chassis	Electronic Brake Control Module																																																										
V	2009	ALL	Body	ISU																								V																																		
V	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module					V																																																					
V	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
V	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2010	ALL	Powertrain	Transmission Control Module 6 Speed		V																																																								
V	2010	ALL	Chassis	Electronic Brake Control Module																																																										
V	2010	ALL	Body	ISU																								V																																		
V	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module					V																																																					
V	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
V	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2011	ALL	Powertrain	Transmission Control Module 6 Speed		V																																																								
V	2011	ALL	Chassis	Electronic Brake Control Module																																																										
V	2011	ALL	Body	ISU																								V																																		
W	2004	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																										
W	2004	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																										
W	2004	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																										
W	2004	ALL	Powertrain	Transmission Control Module																																																										
W	2004	ALL	Body	Body Control Module																																																										
W	2004	ALL	Body	Digital Radio Receiver																																																										
W	2004	ALL	Body	Driver Information Center																																																										
W	2004	ALL	Body	Heating and Air Conditioning																																																										
W	2004	ALL	Body	Instrument Panel Cluster																																																										
W	2004	ALL	Body	Personalization																																																										
W	2004	ALL	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
W	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																									
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																									
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																									
W	2005	ALL	Powertrain	Transmission Control Module																																																									
W	2005	ALL	Body	Body Control Module																																																									
W	2005	ALL	Body	Digital Radio Receiver																																																									
W	2005	ALL	Body	Driver Information Center																																																									
W	2005	ALL	Body	Heating and Air Conditioning																																																									
W	2005	ALL	Body	Instrument Panel Cluster																																																									
W	2005	ALL	Body	Personalization																																																									
W	2005	ALL	Body	Radio																																																									
W	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V								V																																																
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V								V																																																
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V								V																																																
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module				V																																																					
W	2006	ALL	Powertrain	Transmission Control Module																																																									
W	2006	ALL	Chassis	Anti-lock Brake System																																																									
W	2006	ALL	Body	Digital Radio Receiver																																																									
W	2006	ALL	Body	Radio																																																									
W	2006	ALL	Body	Instrument Panel Cluster																																																									
W	2006	ALL	Body	Seat																																	V				V																				
W	2006	ALL	Body	Theft Deterrent Module																																																									
W	2006	ALL	Body	Body Control Module														V	V		V	V	V	V		V	V																																		
W	2006	ALL	Body	HVAC C67 Single																													V																												
W	2006	ALL	Body	HVAC CJ3 Dual																													V																												
W	2006	ALL	Body	Remote Control Door Lock Receiver																																																									
W	2006	ALL	Body	Supplemental Inflatable Restraint																																									V																
W	2006	ALL	Body	Passenger Presence System																																									V																
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V																																																								
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V																																																								
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module				V																																																					
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module	V																																																								
W	2007	ALL	Powertrain	Transmission Control Module																																																									
W	2007	ALL	Chassis	Electronic Brake Control Module																																																									
W	2007	ALL	Body	Body Control Module														V	V	V	V	V		V		V	V																																		
W	2007	ALL	Body	Digital Radio Receiver																																																									
W	2007	ALL	Body	Heated Seat Module																																	V				V																				
W	2007	ALL	Body	HVAC C67 Single																												V	V																												
W	2007	ALL	Body	HVAC CJ3 Dual																													V																												
W	2007	ALL	Body	Instrument Panel Cluster																																																									
W	2007	ALL	Body	Passenger Presence System																																									V																
W	2007	ALL	Body	Radio																																																									
W	2007	ALL	Body	Supplemental Inflatable Restraint																																									V																
W	2007	ALL	Body	Theft Deterrent Module																																																									
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V																																																								
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V																																																								
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module	V																																																								
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module				V																																																					
W	2008	ALL	Powertrain	Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
W	2008	ALL	Chassis	Electronic Brake Control Module													V	V																																											
W	2008	ALL	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V																																		
W	2008	ALL	Body	Digital Radio Receiver																																																										
W	2008	ALL	Body	Heated Seat Module																																	V				V																					
W	2008	ALL	Body	HVAC C67 Single																												V	V																													
W	2008	ALL	Body	HVAC CJ3 Dual																													V																													
W	2008	ALL	Body	Instrument Panel Cluster																																																									
W	2008	ALL	Body	Passenger Presence System																																										V															
W	2008	ALL	Body	Radio																																																									
W	2008	ALL	Body	Remote Control Door Lock Receiver																																																									
W	2008	ALL	Body	Supplemental Inflatable Restraint																																										V															
W	2008	ALL	Body	Theft Deterrent Module																																																									
W	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V			V																																																						
W	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V			V																																																						
W	2009	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module	V			V																																																						
W	2009	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module				V																																																						
W	2009	ALL	Powertrain	Transmission Control Module																																																										
W	2009	ALL	Chassis	Electronic Brake Control Module													V	V																																												
W	2009	ALL	Body	Body Control Module															V	V		V	V		V		V	V																																		
W	2009	ALL	Body	Digital Radio Receiver																																																										
W	2009	ALL	Body	Heated Seat Module																																	V				V																					
W	2009	ALL	Body	HVAC C67 Single																												V	V																													
W	2009	ALL	Body	HVAC CJ3 Dual																													V																													
W	2009	ALL	Body	Instrument Panel Cluster																																																									
W	2009	ALL	Body	Passenger Presence System																																										V															
W	2009	ALL	Body	Radio																																																									
W	2009	ALL	Body	Remote Control Door Lock Receiver																																																									
W	2009	ALL	Body	Supplemental Inflatable Restraint																																										V															
W	2009	ALL	Body	Theft Deterrent Module																																																									
W	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V			V																																																						
W	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V			V																																																						
W	2010	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module	V			V																																																						
W	2010	ALL	Powertrain	Transmission Control Module																																																										
W	2010	ALL	Chassis	Electronic Brake Control Module													V	V																																												
W	2010	ALL	Body	Body Control Module															V	V		V	V		V		V	V																																		
W	2010	ALL	Body	Digital Radio Receiver																																																										
W	2010	ALL	Body	Heated Seat Module																																	V				V																					
W	2010	ALL	Body	HVAC C67 Single																												V	V																													
W	2010	ALL	Body	HVAC CJ3 Dual																													V																													
W	2010	ALL	Body	Instrument Panel Cluster																																																									
W	2010	ALL	Body	Passenger Presence System																																										V															
W	2010	ALL	Body	Radio																																																									
W	2010	ALL	Body	Remote Control Door Lock Receiver																																																									
W	2010	ALL	Body	Supplemental Inflatable Restraint																																										V															
W	2010	ALL	Body	Theft Deterrent Module																																																									
W	2011	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V			V																																																						
W	2011	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module	V			V																																																						
W	2011	ALL	Powertrain	Transmission Control Module																																																										
W	2011	ALL	Chassis	Electronic Brake Control Module													V	V																																												
W	2011	ALL	Body	Body Control Module															V	V		V	V		V		V	V																																		
W	2011	ALL	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
W	2011	ALL	Body	Heated Seat Module																																		V				V																				
W	2011	ALL	Body	HVAC C67 Single																												V	V																												
W	2011	ALL	Body	HVAC CJ3 Dual																													V																													
W	2011	ALL	Body	Instrument Panel Cluster																																																									
W	2011	ALL	Body	Passenger Presence System																																									V																
W	2011	ALL	Body	Radio																																																								
W	2011	ALL	Body	Remote Control Door Lock Receiver																																																								
W	2011	ALL	Body	Supplemental Inflatable Restraint																																									V																
W	2011	ALL	Body	Theft Deterrent Module																																																								
W	2012	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module	V			V					V																																																
W	2012	ALL	Powertrain	Transmission Control Module		V																																																							
W	2012	ALL	Powertrain	Fuel Pump Control Module																																																									
W	2012	ALL	Chassis	Electronic Brake Control Module													V	V																																										
W	2012	ALL	Body	Body Control Module															V	V		V	V		V		V	V																																	
W	2012	ALL	Body	Digital Radio Receiver																																																									
W	2012	ALL	Body	Heated Seat Module																																		V				V																				
W	2012	ALL	Body	HVAC C67 Single																												V	V																												
W	2012	ALL	Body	HVAC CJ3 Dual																													V																													
W	2012	ALL	Body	Instrument Panel Cluster																																																									
W	2012	ALL	Body	Passenger Presence System																																									V																
W	2012	ALL	Body	Radio																																																								
W	2012	ALL	Body	Remote Control Door Lock Receiver																																																								
W	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
W	2012	ALL	Body	Theft Deterrent Module																																																								
W	2013	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module	V			V					V																																																
W	2013	ALL	Powertrain	Transmission Control Module		V																																																							
W	2013	ALL	Powertrain	Fuel Pump Control Module																																																									
W	2013	ALL	Chassis	Electronic Brake Control Module													V	V																																										
W	2013	ALL	Body	Body Control Module															V	V		V	V		V		V	V																																	
W	2013	ALL	Body	Digital Radio Receiver																																																									
W	2013	ALL	Body	Heated Seat Module																																		V				V																				
W	2013	ALL	Body	HVAC C67 Single																												V	V																												
W	2013	ALL	Body	HVAC CJ3 Dual																													V																													
W	2013	ALL	Body	Instrument Panel Cluster																																																									
W	2013	ALL	Body	Passenger Presence System																																									V																
W	2013	ALL	Body	Radio																																																								
W	2013	ALL	Body	Remote Control Door Lock Receiver																																																								
W	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
W	2013	ALL	Body	Theft Deterrent Module																																																									
W	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
W	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
W	2014	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																									
W	2014	Impala	Chassis	Electronic Brake Control Module																																																									
W	2014	Impala	Body	Body Control Module																																																									
W	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
W	2014	Impala	Body	Passenger Presence Module																																																									
W	2014	Impala	Body	Instrument Cluster																																																									
W	2014	Impala	Body	Radio																																																									
W	2014	Impala	Body	Digital Radio Receiver Control Module																																																									
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																									
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
W	2014	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
W	2014	Impala	Body	HVAC Manual Control Single Zone (C67)																																																											
W	2014	Impala	Body	Front Seat Heating Control Module																																																											
W	2014	Impala	Body	Remote Control Door Lock Receiver																																																											
W	2014	Impala	Body	Theft Deterrent Module																																																											
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																											
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																											
W	2014	Lumina	Powertrain	(2) 6.0L L77 Transmission Control Module																																																											
W	2014	Lumina	Powertrain	Fuel Injector Control Module																																																											
W	2014	Lumina	Powertrain	Chassis Control Module																																																											
W	2014	Lumina	Chassis	Electronic Brake Control Module																																																											
W	2014	Lumina	Chassis	Parking Brake Control Module																																																											
W	2014	Lumina	Chassis	Power Steering Control Module																																																											
W	2014	Lumina	Chassis	Steering Wheel Angle Sensor Module																																																											
W	2014	Lumina	Chassis	Suspension Control Module																																																											
W	2014	Lumina	Body	Body Control Module Coupe																																																											
W	2014	Lumina	Body	Body Control Module Sedan																																																											
W	2014	Lumina	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
W	2014	Lumina	Body	Instrument Cluster																																																											
W	2014	Lumina	Body	Head-Up Display Module																																																											
W	2014	Lumina	Body	Radio Control																																																											
W	2014	Lumina	Body	HVAC Control																																																											
W	2014	Lumina	Body	Headlamp Control Module																																																											
W	2014	Lumina	Body	Trailer Interface Control Module																																																											
W	2014	Lumina	Body	Radio																																																											
W	2014	Lumina	Body	HVAC Control Module																																																											
W	2014	Lumina	Body	Keyless Entry Control Module																																																											
W	2014	Lumina	Body	Right Side Object Detection Control Module																																																											
W	2014	Lumina	Body	Left Side Object Detection Control Module																																																											
W	2014	Lumina	Body	Parking Assist Control Module																																																											
W	2014	Lumina	Body	Frontview Camera Module																																																											
W	2014	Lumina	Body	Steering Column Lock Control Module																																																											
W	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
W	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
W	2015	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																											
W	2015	Impala	Chassis	Electronic Brake Control Module																																																											
W	2015	Impala	Body	Body Control Module																																																											
W	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
W	2015	Impala	Body	Passenger Presence Module																																																											
W	2015	Impala	Body	Instrument Cluster																																																											
W	2015	Impala	Body	Radio																																																											
W	2015	Impala	Body	Digital Radio Receiver Control Module																																																											
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 9																																																											
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 10																																																											
W	2015	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
W	2015	Impala	Body	HVAC Manual Control Single Zone (C67)																																																											
W	2015	Impala	Body	Front Seat Heating Control Module																																																											
W	2015	Impala	Body	Remote Control Door Lock Receiver																																																											
W	2015	Impala	Body	Theft Deterrent Module																																																											
W	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
W	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
W	2016	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
W	2016	Impala	Chassis	Electronic Brake Control Module																																																											
W	2016	Impala	Body	Body Control Module																																																										
W	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2016	Impala	Body	Passenger Presence Module																																																										
W	2016	Impala	Body	Instrument Cluster																																																										
W	2016	Impala	Body	Radio																																																										
W	2016	Impala	Body	Digital Radio Receiver Control Module																																																										
W	2016	Impala	Body	Telematics Communication Interface Control Module																																																										
W	2016	Impala	Body	HVAC Manual Control Dual Zone (CJ2)																																																										
W	2016	Impala	Body	HVAC Manual Control Single Zone (C67)																																																										
W	2016	Impala	Body	Front Seat Heating Control Module																																																										
W	2016	Impala	Body	Remote Control Door Lock Receiver																																																										
W	2016	Impala	Body	Theft Deterrent Module																																																										
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Auto																																																										
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Manual																																																										
Y	2004	ALL	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																										
Y	2004	ALL	Powertrain	Transmission Control Module																																																										
Y	2004	ALL	Chassis	RTD																																																										
Y	2004	ALL	Body	Body Control Module																																																										
Y	2004	ALL	Body	Heating and Air Conditioning																																																										
Y	2004	ALL	Body	Instrument Panel Cluster																																																										
Y	2004	ALL	Body	Left Door Control Module																																																										
Y	2004	ALL	Body	Radio																																																										
Y	2004	ALL	Body	Remote Function Actuation																																																										
Y	2004	ALL	Body	Right Door Control Module																																																										
Y	2004	ALL	Body	Seat Control Module																																						V																					
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2005	ALL	Powertrain	Engine Control Module				V																																																							
Y	2005	ALL	Powertrain	Transmission Control Module																																																										
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2005	ALL	Chassis	Electronic Suspension Control																																																										
Y	2005	ALL	Chassis	Steering Wheel and Column																																																										
Y	2005	ALL	Body	Amplifier																																																									
Y	2005	ALL	Body	Body Control Module																					V			V			V																															
Y	2005	ALL	Body	Digital Radio Receiver																																																									
Y	2005	ALL	Body	Driver Door Module																																																									
Y	2005	ALL	Body	Driver Door Switch																																																									
Y	2005	ALL	Body	Driver Position Module																																																									
Y	2005	ALL	Body	Folding Top Module																																																									
Y	2005	ALL	Body	Head Up Display																																																									
Y	2005	ALL	Body	HVAC Control Module																																																									
Y	2005	ALL	Body	Instrument Panel Cluster																																																										
Y	2005	ALL	Body	Navigation Radio																																																										
Y	2005	ALL	Body	Passenger Door Module																																																										
Y	2005	ALL	Body	Radio																																																										
Y	2005	ALL	Body	Remote Control Door Lock Receiver																				V																					V																		
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2006	ALL	Powertrain	Engine Control Module				V																																																							
Y	2006	ALL	Powertrain	Exhaust Flow Control Module																																																											
Y	2006	ALL	Powertrain	Transmission Control Module		V	V																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Y	2006	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2006	ALL	Chassis	Electronic Suspension Control																																																											
Y	2006	ALL	Chassis	Steering Wheel and Column																																																											
Y	2006	ALL	Body	Body Control Module																					V			V			V																																	
Y	2006	ALL	Body	CD Changer																																																										
Y	2006	ALL	Body	Digital Radio Receiver																																																											
Y	2006	ALL	Body	Driver Door Module																																																											
Y	2006	ALL	Body	Driver Door Switch																																																											
Y	2006	ALL	Body	Driver Position Module																																																											
Y	2006	ALL	Body	Folding Top Module																																																											
Y	2006	ALL	Body	Head Up Display																																																											
Y	2006	ALL	Body	HVAC Control Module																													V																															
Y	2006	ALL	Body	Instrument Panel Cluster																																																											
Y	2006	ALL	Body	Navigation Radio																																																											
Y	2006	ALL	Body	Passenger Door Module																																																											
Y	2006	ALL	Body	Radio																																																											
Y	2006	ALL	Body	Remote Control Door Lock Receiver																				V																					V																		
Y	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2007	ALL	Powertrain	Engine Control Module				V																																																								
Y	2007	ALL	Powertrain	Exhaust Flow Control Module																																																												
Y	2007	ALL	Powertrain	Transmission Control Module		V																																																										
Y	2007	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2007	ALL	Chassis	Electronic Suspension Control																																																												
Y	2007	ALL	Body	Body Control Module																					V			V			V																																	
Y	2007	ALL	Body	CD Changer																																																											
Y	2007	ALL	Body	Digital Radio Receiver																																																											
Y	2007	ALL	Body	Driver Door Module																																																											
Y	2007	ALL	Body	Driver Door Switch																																																											
Y	2007	ALL	Body	Driver Position Module																																																											
Y	2007	ALL	Body	Folding Top Module																																																											
Y	2007	ALL	Body	Head Up Display																																																											
Y	2007	ALL	Body	HVAC Control Module																													V																															
Y	2007	ALL	Body	Instrument Panel Cluster																																																											
Y	2007	ALL	Body	Navigation Radio																																																											
Y	2007	ALL	Body	Passenger Door Module																																																											
Y	2007	ALL	Body	Radio																																																											
Y	2007	ALL	Body	Remote Control Door Lock Receiver																				V																					V																		
Y	2007	ALL	Body	Steering Column Lock Module																																																											
Y	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2008	ALL	Powertrain	Engine Control Module				V																																																								
Y	2008	ALL	Powertrain	Exhaust Flow Control Module																																																												
Y	2008	ALL	Powertrain	Transmission Control Module		V																																																										
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2008	ALL	Chassis	Electronic Suspension Control																																																												
Y	2008	ALL	Body	Body Control Module																					V			V			V																																	
Y	2008	ALL	Body	CD Changer																																																											
Y	2008	ALL	Body	Digital Radio Receiver																																																											
Y	2008	ALL	Body	Driver Door Module																																																											
Y	2008	ALL	Body	Driver Door Switch																																																											
Y	2008	ALL	Body	Driver Position Module																																																											
Y	2008	ALL	Body	Folding Top Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Y	2008	ALL	Body	Head Up Display																																																											
Y	2008	ALL	Body	HVAC Control Module																													V																														
Y	2008	ALL	Body	Instrument Panel Cluster																																																										
Y	2008	ALL	Body	Navigation Radio																																																										
Y	2008	ALL	Body	Passenger Door Module																																																										
Y	2008	ALL	Body	Radio																																																										
Y	2008	ALL	Body	Personal Audio Link Module																																																										
Y	2008	ALL	Body	Remote Control Door Lock Receiver																				V																						V																	
Y	2008	ALL	Body	Steering Column Lock Module																																																										
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module				V																																																						
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module		V																																																								
Y	2009	ALL	Chassis	Electronic Brake Control Module						V							V																																													
Y	2009	ALL	Chassis	Electronic Suspension Control																																																										
Y	2009	ALL	Body	Body Control Module																					V			V			V																																
Y	2009	ALL	Body	CD Changer																																																									
Y	2009	ALL	Body	Digital Radio Receiver																																																										
Y	2009	ALL	Body	Driver Door Module																																																										
Y	2009	ALL	Body	Driver Door Switch																																																										
Y	2009	ALL	Body	Driver Position Module																																																										
Y	2009	ALL	Body	Folding Top Module																																																										
Y	2009	ALL	Body	Head Up Display																																																										
Y	2009	ALL	Body	HVAC Control Module																													V																														
Y	2009	ALL	Body	Instrument Panel Cluster																																																										
Y	2009	ALL	Body	Navigation Radio																																																										
Y	2009	ALL	Body	Passenger Door Module																																																										
Y	2009	ALL	Body	Radio																																																										
Y	2009	ALL	Body	Personal Audio Link Module																																																										
Y	2009	ALL	Body	Remote Control Door Lock Receiver																				V																						V																	
Y	2009	ALL	Body	Steering Column Lock Module																																																										
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module	V			V																																																						
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module		V																																																								
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module	V			V																																																						
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module	V			V																																																						
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2010	ALL	Chassis	Electronic Brake Control Module						V							V																																													
Y	2010	ALL	Chassis	Electronic Suspension Control																																																										
Y	2010	ALL	Body	Body Control Module																					V			V			V																																
Y	2010	ALL	Body	CD Changer																																																									
Y	2010	ALL	Body	Digital Radio Receiver																																																										
Y	2010	ALL	Body	Driver Door Module																																																										
Y	2010	ALL	Body	Driver Door Switch																																																										
Y	2010	ALL	Body	Driver Position Module																																																										
Y	2010	ALL	Body	Folding Top Module																																																										
Y	2010	ALL	Body	Head Up Display																																																										
Y	2010	ALL	Body	HVAC Control Module																													V																														

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Y	2010	ALL	Body	Instrument Panel Cluster																																																									
Y	2010	ALL	Body	Navigation Radio																																																									
Y	2010	ALL	Body	Passenger Door Module																																																									
Y	2010	ALL	Body	Radio																																																									
Y	2010	ALL	Body	Personal Audio Link Module																																																									
Y	2010	ALL	Body	Remote Control Door Lock Receiver																				V																						V															
Y	2010	ALL	Body	Steering Column Lock Module																																																									
Y	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module	V			V																																																					
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module		V																																																								
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module	V			V																																																						
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module	V			V																																																						
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2011	ALL	Chassis	Electronic Brake Control Module						V							V																																													
Y	2011	ALL	Chassis	Electronic Suspension Control																																																											
Y	2011	ALL	Body	Body Control Module																					V			V			V																																
Y	2011	ALL	Body	CD Changer																																																										
Y	2011	ALL	Body	Digital Radio Receiver																																																										
Y	2011	ALL	Body	Driver Door Module																																																										
Y	2011	ALL	Body	Driver Door Switch																																																										
Y	2011	ALL	Body	Driver Position Module																																																										
Y	2011	ALL	Body	Folding Top Module																																																										
Y	2011	ALL	Body	Head Up Display																																																										
Y	2011	ALL	Body	HVAC Control Module																													V																														
Y	2011	ALL	Body	Instrument Panel Cluster																																																										
Y	2011	ALL	Body	Navigation Radio																																																										
Y	2011	ALL	Body	Passenger Door Module																																																										
Y	2011	ALL	Body	Radio																																																										
Y	2011	ALL	Body	Personal Audio Link Module																																																										
Y	2011	ALL	Body	Remote Control Door Lock Receiver																				V																						V															
Y	2011	ALL	Body	Steering Column Lock Module																																																										
Y	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module	V			V																																																					
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module		V																																																								
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module	V			V																																																						
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module	V			V																																																						
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2012	ALL	Chassis	Electronic Brake Control Module						V							V																																													
Y	2012	ALL	Chassis	Electronic Suspension Control																																																											
Y	2012	ALL	Body	Body Control Module																					V			V			V																																
Y	2012	ALL	Body	CD Changer																																																										
Y	2012	ALL	Body	Digital Radio Receiver																																																										
Y	2012	ALL	Body	Driver Door Module																																																										
Y	2012	ALL	Body	Driver Door Switch																																																										
Y	2012	ALL	Body	Driver Position Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Y	2012	ALL	Body	Folding Top Module																																																										
Y	2012	ALL	Body	Head Up Display																																																										
Y	2012	ALL	Body	HVAC Control Module																													V																														
Y	2012	ALL	Body	Instrument Panel Cluster																																																										
Y	2012	ALL	Body	Navigation Radio																																																										
Y	2012	ALL	Body	Passenger Door Module																																																										
Y	2012	ALL	Body	Radio																																																										
Y	2012	ALL	Body	Personal Audio Link Module																																																										
Y	2012	ALL	Body	Remote Control Door Lock Receiver																				V																						V																
Y	2012	ALL	Body	Steering Column Lock Module																																																										
Y	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module	V			V																																																						
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module		V																																																								
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module	V			V																																																						
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module	V			V																																																						
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2013	ALL	Chassis	Electronic Brake Control Module						V							V																																													
Y	2013	ALL	Chassis	Electronic Suspension Control																																																										
Y	2013	ALL	Body	Body Control Module																					V			V			V																																
Y	2013	ALL	Body	CD Changer																																																									
Y	2013	ALL	Body	Digital Radio Receiver																																																									
Y	2013	ALL	Body	Driver Door Module																																																									
Y	2013	ALL	Body	Driver Door Switch																																																									
Y	2013	ALL	Body	Driver Position Module																																																									
Y	2013	ALL	Body	Folding Top Module																																																									
Y	2013	ALL	Body	Head Up Display																																																									
Y	2013	ALL	Body	HVAC Control Module																													V																														
Y	2013	ALL	Body	Instrument Panel Cluster																																																										
Y	2013	ALL	Body	Navigation Radio																																																										
Y	2013	ALL	Body	Passenger Door Module																																																										
Y	2013	ALL	Body	Radio																																																										
Y	2013	ALL	Body	Personal Audio Link Module																																																										
Y	2013	ALL	Body	Remote Control Door Lock Receiver																				V																						V																
Y	2013	ALL	Body	Steering Column Lock Module																																																										
Y	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																										
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																										
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																										
Y	2014	Corvette	Powertrain	Chassis Control Module																																																										
Y	2014	Corvette	Chassis	Electronic Brake Control Module																																																										
Y	2014	Corvette	Chassis	Parking Brake Control Module																																																										
Y	2014	Corvette	Chassis	Power Steering Control Module																																																										
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																										
Y	2014	Corvette	Chassis	Suspension Control Module																																																										
Y	2014	Corvette	Body	Body Control Module Convertible																																																										
Y	2014	Corvette	Body	Body Control Module Coupe																																																										
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Y	2014	Corvette	Body	Passenger Presence Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Y	2014	Corvette	Body	Instrument Cluster																																																										
Y	2014	Corvette	Body	Radio/HVAC Control																																																										
Y	2014	Corvette	Body	Inside Rearview Mirror																																																										
Y	2014	Corvette	Body	Radio																																																										
Y	2014	Corvette	Body	Amplifier																																																										
Y	2014	Corvette	Body	Human Machine Interface Control Module																																																										
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2014	Corvette	Body	HVAC Control Module																																																										
Y	2014	Corvette	Body	Seat Memory Control Module - Passenger																																																										
Y	2014	Corvette	Body	Seat Memory Control Module - Driver																																																										
Y	2014	Corvette	Body	Folding Top Control Module																																																										
Y	2014	Corvette	Body	Keyless Entry Control Module																																																										
Y	2014	Corvette	Body	Steering Column Lock Control Module																																																										
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																										
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																										
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																										
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Automatic Transmission																																																										
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Manual Transmission																																																										
Y	2015	Corvette	Powertrain	6.2L LT4 Transmission Control Module																																																										
Y	2015	Corvette	Powertrain	Chassis Control Module																																																										
Y	2015	Corvette	Chassis	Electronic Brake Control Module																																																										
Y	2015	Corvette	Chassis	Parking Brake Control Module																																																										
Y	2015	Corvette	Chassis	Power Steering Control Module																																																										
Y	2015	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																										
Y	2015	Corvette	Chassis	Suspension Control Module																																																										
Y	2015	Corvette	Body	Body Control Module Convertible																																																										
Y	2015	Corvette	Body	Body Control Module Coupe																																																										
Y	2015	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Y	2015	Corvette	Body	Passenger Presence Module																																																										
Y	2015	Corvette	Body	Instrument Cluster																																																										
Y	2015	Corvette	Body	Radio/HVAC Control																																																										
Y	2015	Corvette	Body	Vehicle Performance Data Recorder																																																										
Y	2015	Corvette	Body	Inside Rearview Mirror																																																										
Y	2015	Corvette	Body	Radio																																																										
Y	2015	Corvette	Body	Amplifier																																																										
Y	2015	Corvette	Body	Human Machine Interface Control Module																																																										
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2015	Corvette	Body	HVAC Control Module																																																										
Y	2015	Corvette	Body	Seat Memory Control Module - Passenger																																																										
Y	2015	Corvette	Body	Seat Memory Control Module - Driver																																																										
Y	2015	Corvette	Body	Folding Top Control Module																																																										
Y	2015	Corvette	Body	Keyless Entry Control Module																																																										
Y	2015	Corvette	Body	Steering Column Lock Control Module																																																										
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																										
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																										
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Automatic Transmission																																																										
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Manual Transmission																																																										
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Y	2016	Corvette	Powertrain	Rear Differential Clutch Control Module																																																										
Y	2016	Corvette	Chassis	Electronic Brake Control Module																																																											
Y	2016	Corvette	Chassis	Parking Brake Control Module																																																											
Y	2016	Corvette	Chassis	Power Steering Control Module																																																											
Y	2016	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																											
Y	2016	Corvette	Chassis	Suspension Control Module																																																											
Y	2016	Corvette	Body	Body Control Module																																																											
Y	2016	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
Y	2016	Corvette	Body	Passenger Presence Module																																																											
Y	2016	Corvette	Body	Instrument Cluster																																																											
Y	2016	Corvette	Body	Radio/HVAC Control																																																											
Y	2016	Corvette	Body	Vehicle Performance Data Recorder																																																											
Y	2016	Corvette	Body	Video Processing Control Module																																																											
Y	2016	Corvette	Body	Inside Rearview Mirror																																																											
Y	2016	Corvette	Body	Radio																																																											
Y	2016	Corvette	Body	Amplifier																																																											
Y	2016	Corvette	Body	Human Machine Interface Control Module																																																											
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																											
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																											
Y	2016	Corvette	Body	HVAC Control Module																																																											
Y	2016	Corvette	Body	Liftgate Control Module																																																											
Y	2016	Corvette	Body	Seat Memory Control Module - Passenger																																																											
Y	2016	Corvette	Body	Seat Memory Control Module - Driver																																																											
Y	2016	Corvette	Body	Folding Top Control Module																																																											
Y	2016	Corvette	Body	Keyless Entry Control Module																																																											
Y	2016	Corvette	Body	Steering Column Lock Control Module																																																											
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																											
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																											
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																											
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																											
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																											
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																											
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																											
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																											
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																											
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																											
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																											
Y	2016	Cruze	Chassis	Electronic Brake Control Module																																																											
Y	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																											
Y	2016	Cruze	Chassis	Power Steering Control Module																																																											
Y	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
Y	2016	Cruze	Body	Body Control Module																																																											
Y	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
Y	2016	Cruze	Body	Passenger Presence Module																																																											
Y	2016	Cruze	Body	Instrument Cluster																																																											
Y	2016	Cruze	Body	Radio Controls																																																											
Y	2016	Cruze	Body	HVAC Controls																																																											
Y	2016	Cruze	Body	Trailer Interface Control Module																																																											
Y	2016	Cruze	Body	Radio Base (IO3 IO7)																																																											
Y	2016	Cruze	Body	Radio (IOA)																																																											
Y	2016	Cruze	Body	Radio (IOB)																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Y	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																										
Y	2016	Cruze	Body	Amplifier																																																										
Y	2016	Cruze	Body	Multimedia Player Interface Module																																																										
Y	2016	Cruze	Body	Human Machine Interface Control Module																																																										
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
Y	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																										
Y	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																										
Y	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																										
Y	2016	Cruze	Body	Keyless Entry Control Module																																																										
Y	2016	Cruze	Body	Right Side Object Detection Control Module																																																										
Y	2016	Cruze	Body	Left Side Object Detection Control Module																																																										
Y	2016	Cruze	Body	Parking Assist Control Module																																																										
Y	2016	Cruze	Body	Frontview Camera Module																																																										
Y	2016	Cruze	Body	Steering Column Lock Control Module																																																										
Y	2016	Cruze	Body	Long Range Radar Sensor Module																																																										
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																										
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Transmission Control Module																																																										
Z	2004	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2004	ALL	Chassis	Power Steering Control Module																																																										
Z	2004	ALL	Body	Body Control Module																					V	V		V			V																																
Z	2004	ALL	Body	Digital Radio Receiver																																																										
Z	2004	ALL	Body	HVAC Control Module																																								V																		
Z	2004	ALL	Body	Instrument Panel Cluster																																																										
Z	2004	ALL	Body	Radio																																																										
Z	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2004	ALL	Body	Theft Deterrent Module																																																										
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2005	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																										
Z	2005	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2005	ALL	Chassis	Power Steering Control Module																																																										
Z	2005	ALL	Body	Body Control Module																					V	V		V			V																																
Z	2005	ALL	Body	Digital Radio Receiver																																																										
Z	2005	ALL	Body	HVAC Control Module																																								V																		
Z	2005	ALL	Body	Instrument Panel Cluster																																																										
Z	2005	ALL	Body	Radio																																																										
Z	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2005	ALL	Body	Theft Deterrent Module																																																										
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2006	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																										
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V																																																									
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
Z	2006	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2006	ALL	Chassis	Power Steering Control Module																																																										
Z	2006	ALL	Body	Body Control Module																					V	V		V			V																																
Z	2006	ALL	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Z	2006	ALL	Body	HVAC Control Module																																							V																		
Z	2006	ALL	Body	Instrument Panel Cluster																																																								
Z	2006	ALL	Body	Radio																																																								
Z	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2006	ALL	Body	Theft Deterrent Module																																																								
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module										V																																															
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																									
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V			V						V																																															
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																									
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V			V						V																																															
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																									
Z	2007	ALL	Chassis	Electronic Brake Control Module																																																									
Z	2007	ALL	Chassis	Power Steering Control Module																																																									
Z	2007	ALL	Body	Body Control Module																					V	V		V			V																															
Z	2007	ALL	Body	Digital Radio Receiver																																																									
Z	2007	ALL	Body	Disc Player and Video Display																																																									
Z	2007	ALL	Body	HVAC Control Module																																							V																		
Z	2007	ALL	Body	Instrument Panel Cluster																																																									
Z	2007	ALL	Body	Radio																																																									
Z	2007	ALL	Body	Remote Control Door Lock Receiver																																																									
Z	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
Z	2007	ALL	Body	Theft Deterrent Module																																																									
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module										V																																															
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																									
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module	V			V																																																					
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed		V																																																							
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																									
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V			V																																																					
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																									
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V																																																								
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module		V																																																							
Z	2008	ALL	Chassis	Electronic Brake Control Module																																																									
Z	2008	ALL	Chassis	Power Steering Control Module																																																									
Z	2008	ALL	Body	Body Control Module Classic																					V	V		V			V																															
Z	2008	ALL	Body	Body Control Module Malibu																					V	V		V			V																															
Z	2008	ALL	Body	Digital Radio Receiver																																																									
Z	2008	ALL	Body	Disc Player and Video Display																																																									
Z	2008	ALL	Body	HVAC Control Module Classic																																							V																		
Z	2008	ALL	Body	HVAC Control Module Malibu																																							V																		
Z	2008	ALL	Body	Instrument Panel Cluster Classic																																																									
Z	2008	ALL	Body	Instrument Panel Cluster Malibu																																																									
Z	2008	ALL	Body	Radio																																																									
Z	2008	ALL	Body	Remote Control Door Lock Receiver																																																									
Z	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
Z	2008	ALL	Body	Theft Deterrent Module																																																									
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module	V			V																																																					
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed		V																																																							
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																									
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump	V			V																																																					
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump	V			V																																																					
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Without Tap Shift																																																										
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V			V																																																						
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																											
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V			V																																																							
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module		V																																																									
Z	2009	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2009	ALL	Chassis	Power Steering Control Module																																																											
Z	2009	ALL	Body	Body Control Module																					V	V		V			V																																	
Z	2009	ALL	Body	Digital Radio Receiver																																																											
Z	2009	ALL	Body	Disc Player and Video Display																																																											
Z	2009	ALL	Body	HVAC Control Module																																							V																				
Z	2009	ALL	Body	Instrument Panel Cluster																																																											
Z	2009	ALL	Body	Personal Audio Link Module																																																											
Z	2009	ALL	Body	Radio																																																											
Z	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2009	ALL	Body	Theft Deterrent Module																																																											
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module	V			V																																																							
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed		V																																																									
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																											
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Engine Control Module	V			V																																																							
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 6 Speed		V																																																									
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 4 Speed																																																											
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module	V			V																																																							
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																												
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module	V			V																																																								
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																												
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V			V																																																								
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module		V																																																										
Z	2010	ALL	Chassis	Electronic Brake Control Module																																																												
Z	2010	ALL	Chassis	Power Steering Control Module																																																												
Z	2010	ALL	Body	Body Control Module																					V	V		V			V																																	
Z	2010	ALL	Body	Digital Radio Receiver																																																												
Z	2010	ALL	Body	HVAC Control Module																																							V																				
Z	2010	ALL	Body	Instrument Panel Cluster																																																											
Z	2010	ALL	Body	Personal Audio Link Module																																																												
Z	2010	ALL	Body	Radio																																																											
Z	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2010	ALL	Body	Theft Deterrent Module																																																											
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module	V			V																																																							
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module		V																																																									
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Engine Control Module	V			V																																																							
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Transmission Control Module		V																																																									
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V			V																																																							
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module		V																																																									
Z	2011	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2011	ALL	Chassis	Power Steering Control Module																																																											
Z	2011	ALL	Body	Body Control Module																					V	V		V			V																																	
Z	2011	ALL	Body	Digital Radio Receiver																																																											
Z	2011	ALL	Body	HVAC Control Module																																							V																				
Z	2011	ALL	Body	Instrument Panel Cluster																																																											
Z	2011	ALL	Body	Personal Audio Link Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Z	2011	ALL	Body	Radio																																																											
Z	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2011	ALL	Body	Theft Deterrent Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Engine Control Module	V			V																																																							
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Transmission Control Module		V																																																									
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Engine Control Module	V			V																																																							
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Transmission Control Module		V																																																									
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Engine Control Module	V			V																																																							
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Transmission Control Module		V																																																									
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V			V																																																							
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Transmission Control Module		V																																																									
Z	2012	Malibu (Seventh Gen)	Chassis	Electronic Brake Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Chassis	Power Steering Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Body	Body Control Module																					V	V		V			V																																
Z	2012	Malibu (Seventh Gen)	Body	Digital Radio Receiver																																																											
Z	2012	Malibu (Seventh Gen)	Body	HVAC Control Module																																								V																			
Z	2012	Malibu (Seventh Gen)	Body	Instrument Panel Cluster																																																											
Z	2012	Malibu (Seventh Gen)	Body	Personal Audio Link Module																																																											
Z	2012	Malibu (Seventh Gen)	Body	Radio																																																											
Z	2012	Malibu (Seventh Gen)	Body	Supplemental Inflatable Restraint																																																											
Z	2012	Malibu (Seventh Gen)	Body	Theft Deterrent Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Fuel Pump Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Fuel Pump Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	Rear Differential Clutch Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Electronic Brake Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Parking Brake Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Power Steering Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Steering Wheel Angle Sensor Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Suspension Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																											
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																											
Z	2012	Malibu (Eighth Gen)	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Z	2012	Malibu (Eighth Gen)	Body	Instrument Cluster																																																										
Z	2012	Malibu (Eighth Gen)	Body	Head-Up Display Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Headlamp Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Radio																																																										
Z	2012	Malibu (Eighth Gen)	Body	Digital Radio Receiver Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Multimedia Player Interface Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Mobile Telephone Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Dual (CJ2)																																																										
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Single (C68)																																																										
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Manual Single (C67)																																																										
Z	2012	Malibu (Eighth Gen)	Body	Rear Seat Heating Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Keyless Entry Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Right Side Object Detection Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Left Side Object Detection Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Parking Assist Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Vehicle Direction Camera Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Steering Column Lock Control Module																																																										
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Engine Control Module																																																										
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Transmission Control Module																																																										
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Engine Control Module																																																										
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 1																																																										
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 2																																																										
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 6 Speed (MNM)																																																										
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 8 Speed (MRC)																																																										
Z	2016	Malibu	Chassis	Electronic Brake Control Module																																																										
Z	2016	Malibu	Chassis	Brake Booster Control Module																																																										
Z	2016	Malibu	Chassis	Power Steering Control Module																																																										
Z	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
Z	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
Z	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Z	2016	Malibu	Body	Passenger Presence Module																																																										
Z	2016	Malibu	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
Z	2016	Malibu	Body	Instrument Cluster Enhanced Monochrome Driver Info Center (UDC)																																																										
Z	2016	Malibu	Body	Radio Controls																																																										
Z	2016	Malibu	Body	HVAC Controls																																																										
Z	2016	Malibu	Body	Active Safety Control Module																																																										
Z	2016	Malibu	Body	Headlamp Control Module																																																										
Z	2016	Malibu	Body	Radio Base																																																										
Z	2016	Malibu	Body	Radio (IOA)																																																										
Z	2016	Malibu	Body	Radio Uplevel (IO4 IO5 IO6)																																																										
Z	2016	Malibu	Body	Amplifier																																																										
Z	2016	Malibu	Body	Human Machine Interface Control Module																																																										
Z	2016	Malibu	Body	Navigation Control Module																																																										
Z	2016	Malibu	Body	Mobile Telephone Control Module																																																										
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																										
Z	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
Z	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
Z	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
Z	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
Z	2016	Malibu	Body	Electric A/C Compressor Control Module																																																										
Z	2016	Malibu	Body	Seat Memory Control Module - Driver																																																										
Z	2016	Malibu	Body	Keyless Entry Control Module																																																										
Z	2016	Malibu	Body	Right Side Object Detection Control Module																																																										
Z	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
Z	2016	Malibu	Body	Parking Assist Control Module																																																										
Z	2016	Malibu	Body	Frontview Camera Module																																																										
Z	2016	Malibu	Body	Frontview Camera Module																																																										
Z	2016	Malibu	Body	Steering Column Lock Control Module																																																										
Z	2016	Malibu	Body	Long Range Radar Sensor Module																																																										
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
1	2013	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2013	Malibu	Chassis	Parking Brake Control Module																																																										
1	2013	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2013	Malibu	Chassis	Power Steering Control Module																																																										
1	2013	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2013	Malibu	Chassis	Suspension Control Module																																																										
1	2013	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2013	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																										
1	2013	Malibu	Body	Passenger Presence Module																																																											
1	2013	Malibu	Body	Instrument Cluster																																																											
1	2013	Malibu	Body	Headlamp Control Module																																																											
1	2013	Malibu	Body	Radio																																																											
1	2013	Malibu	Body	Digital Radio Receiver Control Module																																																											
1	2013	Malibu	Body	Multimedia Player Interface Module																																																											
1	2013	Malibu	Body	Mobile Telephone Control Module																																																											
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2013	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
1	2013	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											
1	2013	Malibu	Body	HVAC Control Module Manual Single (C67)																																																											
1	2013	Malibu	Body	Rear Seat Heating Control Module																																																											
1	2013	Malibu	Body	Keyless Entry Control Module																																																											
1	2013	Malibu	Body	Parking Assist Control Module																																																											
1	2013	Malibu	Body	Vehicle Direction Camera Control Module																																																											
1	2013	Malibu	Body	Steering Column Lock Control Module																																																											
1	2013	Malibu	Body	Battery Energy Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																											
1	2014	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																											
1	2014	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																											
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																											
1	2014	Impala	Chassis	Electronic Brake Control Module																																																											
1	2014	Impala	Chassis	Distance Sensing Cruise Control Module																																																											
1	2014	Impala	Chassis	Parking Brake Control Module																																																											
1	2014	Impala	Chassis	Power Steering Control Module																																																											
1	2014	Impala	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2014	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	Impala	Body	Passenger Presence Module																																																											
1	2014	Impala	Body	Instrument Cluster																																																											
1	2014	Impala	Body	Radio Control																																																											
1	2014	Impala	Body	HVAC Control																																																											
1	2014	Impala	Body	Radio																																																											
1	2014	Impala	Body	Amplifier																																																											
1	2014	Impala	Body	Human Machine Interface Control Module																																																											
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Impala	Body	HVAC Control Module																																																											
1	2014	Impala	Body	Keyless Entry Control Module																																																											
1	2014	Impala	Body	Right Side Object Detection Control Module																																																											
1	2014	Impala	Body	Left Side Object Detection Control Module																																																											
1	2014	Impala	Body	Parking Assist Control Module																																																											
1	2014	Impala	Body	Frontview Camera Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2014	Impala	Body	Steering Column Lock Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
1	2014	Malibu	Chassis	Electronic Brake Control Module																																																											
1	2014	Malibu	Chassis	Parking Brake Control Module																																																											
1	2014	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2014	Malibu	Chassis	Power Steering Control Module																																																											
1	2014	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Malibu	Chassis	Suspension Control Module																																																											
1	2014	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2014	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																											
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																											
1	2014	Malibu	Body	Passenger Presence Module																																																											
1	2014	Malibu	Body	Instrument Cluster																																																											
1	2014	Malibu	Body	Headlamp Control Module																																																											
1	2014	Malibu	Body	Radio																																																										
1	2014	Malibu	Body	Digital Radio Receiver Control Module																																																											
1	2014	Malibu	Body	Multimedia Player Interface Module																																																											
1	2014	Malibu	Body	Mobile Telephone Control Module																																																											
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
1	2014	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2014	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2014	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
1	2014	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2014	Malibu	Body	Keyless Entry Control Module																																																										
1	2014	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2014	Malibu	Body	Parking Assist Control Module																																																										
1	2014	Malibu	Body	Frontview Camera Module																																																										
1	2014	Malibu	Body	Steering Column Lock Control Module																																																										
1	2015	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																										
1	2015	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																										
1	2015	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																										
1	2015	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																										
1	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																										
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																										
1	2015	Impala	Chassis	Electronic Brake Control Module																																																										
1	2015	Impala	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Impala	Chassis	Parking Brake Control Module																																																										
1	2015	Impala	Chassis	Power Steering Control Module																																																										
1	2015	Impala	Chassis	Power Steering Control Module																																																										
1	2015	Impala	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2015	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Impala	Body	Passenger Presence Module																																																										
1	2015	Impala	Body	Instrument Cluster																																																										
1	2015	Impala	Body	Radio Control																																																										
1	2015	Impala	Body	HVAC Control																																																										
1	2015	Impala	Body	Radio																																																										
1	2015	Impala	Body	Amplifier																																																										
1	2015	Impala	Body	Human Machine Interface Control Module																																																										
1	2015	Impala	Body	Telematics Communication Interface Control Module																																																										
1	2015	Impala	Body	HVAC Control Module																																																										
1	2015	Impala	Body	Keyless Entry Control Module																																																										
1	2015	Impala	Body	Right Side Object Detection Control Module																																																										
1	2015	Impala	Body	Left Side Object Detection Control Module																																																										
1	2015	Impala	Body	Parking Assist Control Module																																																										
1	2015	Impala	Body	Frontview Camera Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Chassis Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBS Chassis Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2015	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																									
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																									
1	2015	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																									
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	2.4L LE9 Chassis Control Module																																																									
1	2015	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																									
1	2015	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																									
1	2015	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																									
1	2015	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																									
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																									
1	2015	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																									
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	3.0L LFW Chassis Control Module																																																									
1	2015	Malibu	Powertrain	3.0L LFW Transmission Control Module																																																									
1	2015	Malibu	Powertrain	Rear Differential Clutch Control Module																																																									
1	2015	Malibu	Chassis	Electronic Brake Control Module																																																									
1	2015	Malibu	Chassis	Parking Brake Control Module																																																									
1	2015	Malibu	Chassis	Power Steering Control Module																																																									
1	2015	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2015	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
1	2015	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
1	2015	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2015	Malibu	Body	Passenger Presence Module																																																									
1	2015	Malibu	Body	Instrument Cluster																																																									
1	2015	Malibu	Body	Headlamp Control Module																																																									
1	2015	Malibu	Body	Radio																																																								
1	2015	Malibu	Body	Digital Radio Receiver Control Module																																																									
1	2015	Malibu	Body	Multimedia Player Interface Module																																																									
1	2015	Malibu	Body	Mobile Telephone Control Module																																																									
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																									
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2015	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																									
1	2015	Malibu	Body	HVAC Control Module Auto Single (C68)																																																									
1	2015	Malibu	Body	HVAC Control Module Manual Single (C67)																																																									
1	2015	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																									
1	2015	Malibu	Body	Front Seat Heating Control Module																																																									
1	2015	Malibu	Body	Rear Seat Heating Control Module																																																									
1	2015	Malibu	Body	Keyless Entry Control Module																																																									
1	2015	Malibu	Body	Left Side Object Detection Control Module																																																									
1	2015	Malibu	Body	Parking Assist Control Module																																																									
1	2015	Malibu	Body	Frontview Camera Module																																																									
1	2015	Malibu	Body	Steering Column Lock Control Module																																																									
1	2015	Malibu (LSG)	Powertrain	1.6L LLU Engine Control Module																																																									
1	2015	Malibu (LSG)	Powertrain	Transmission Control Module																																																									
1	2015	Malibu (LSG)	Powertrain	Rear Differential Clutch Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2015	Malibu (LSG)	Chassis	Electronic Brake Control Module																																																											
1	2015	Malibu (LSG)	Chassis	Parking Brake Control Module																																																											
1	2015	Malibu (LSG)	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2015	Malibu (LSG)	Chassis	Suspension Control Module																																																											
1	2015	Malibu (LSG)	Body	Body Control Module																																																											
1	2015	Malibu (LSG)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	Malibu (LSG)	Body	Instrument Cluster																																																											
1	2015	Malibu (LSG)	Body	Headlamp Control Module																																																											
1	2015	Malibu (LSG)	Body	Radio																																																											
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2015	Malibu (LSG)	Body	HVAC Control Module																																																											
1	2015	Malibu (LSG)	Body	Front Seat Heating Control Module																																																											
1	2015	Malibu (LSG)	Body	Keyless Entry Control Module																																																											
1	2015	Malibu (LSG)	Body	Left Side Object Detection Control Module																																																											
1	2015	Malibu (LSG)	Body	Parking Assist Control Module																																																											
1	2015	Malibu (LSG)	Body	Frontview Camera Module																																																											
1	2015	Malibu (LSG)	Body	Steering Column Lock Control Module																																																											
1	2016	Impala	Powertrain	(A) 2.5L LCV Engine Control Module																																																											
1	2016	Impala	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
1	2016	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																											
1	2016	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																											
1	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2016	Impala	Powertrain	Chassis Control Module																																																											
1	2016	Impala	Chassis	Electronic Brake Control Module																																																											
1	2016	Impala	Chassis	Distance Sensing Cruise Control Module																																																											
1	2016	Impala	Chassis	Parking Brake Control Module																																																											
1	2016	Impala	Chassis	Power Steering Control Module																																																											
1	2016	Impala	Chassis	Power Steering Control Module																																																											
1	2016	Impala	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2016	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2016	Impala	Body	Passenger Presence Module																																																											
1	2016	Impala	Body	Instrument Cluster																																																											
1	2016	Impala	Body	Radio Control																																																											
1	2016	Impala	Body	HVAC Control																																																											
1	2016	Impala	Body	Radio																																																											
1	2016	Impala	Body	Amplifier																																																											
1	2016	Impala	Body	Human Machine Interface Control Module																																																											
1	2016	Impala	Body	Navigation Control Module																																																											
1	2016	Impala	Body	Telematics Communication Interface Control Module																																																											
1	2016	Impala	Body	HVAC Control Module																																																											
1	2016	Impala	Body	Seat Memory Control Module - Driver																																																											
1	2016	Impala	Body	Keyless Entry Control Module																																																											
1	2016	Impala	Body	Right Side Object Detection Control Module																																																											
1	2016	Impala	Body	Left Side Object Detection Control Module																																																											
1	2016	Impala	Body	Parking Assist Control Module																																																											
1	2016	Impala	Body	Frontview Camera Module																																																											
1	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2016	Malibu	Powertrain	Fuel Injector Control Module																																																										
1	2016	Malibu	Powertrain	Chassis Control Module																																																										
1	2016	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2016	Malibu	Chassis	Parking Brake Control Module																																																										
1	2016	Malibu	Chassis	Power Steering Control Module																																																										
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Malibu	Body	Passenger Presence Module																																																										
1	2016	Malibu	Body	Instrument Cluster																																																										
1	2016	Malibu	Body	Headlamp Control Module																																																										
1	2016	Malibu	Body	Radio																																																										
1	2016	Malibu	Body	Digital Radio Receiver Control Module																																																										
1	2016	Malibu	Body	Multimedia Player Interface Module																																																										
1	2016	Malibu	Body	Mobile Telephone Control Module																																																										
1	2016	Malibu	Body	Telematics Communication Interface Control Module																																																										
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
1	2016	Malibu	Body	Seat Memory Control Module																																																										
1	2016	Malibu	Body	Front Seat Heating Control Module																																																										
1	2016	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2016	Malibu	Body	Keyless Entry Control Module																																																										
1	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2016	Malibu	Body	Parking Assist Control Module																																																										
1	2016	Malibu	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2005	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																														
A	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																														
A	2005	ALL	Powertrain	Transmission Control Module																																																														
A	2005	ALL	Chassis	Power Steering Control Module																																																														
A	2005	ALL	Chassis	Anti-lock Brake System																																																														
A	2005	ALL	Body	Body Control Module																																																														
A	2005	ALL	Body	Digital Radio Receiver																																																														
A	2005	ALL	Body	Instrument Panel																																																														
A	2005	ALL	Body	Radio																																																														
A	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
A	2006	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																														
A	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																														
A	2006	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																														
A	2006	ALL	Powertrain	Transmission Control Module																																																														
A	2006	ALL	Chassis	Power Steering Control Module																																																														
A	2006	ALL	Chassis	Anti-lock Brake System																																																														
A	2006	ALL	Body	Body Control Module																																																														
A	2006	ALL	Body	Digital Radio Receiver																																																														
A	2006	ALL	Body	Instrument Panel																																																														
A	2006	ALL	Body	Radio																																																														
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																														
A	2006	ALL	Body	Theft Deterrent Module																																																														
A	2007	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																														
A	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																														
A	2007	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																														
A	2007	ALL	Powertrain	Transmission Control Module																																																														
A	2007	ALL	Chassis	Power Steering Control Module																																																														
A	2007	ALL	Chassis	Electronic Brake Control Module																																																														
A	2007	ALL	Body	Body Control Module																																																														
A	2007	ALL	Body	Digital Radio Receiver																																																														
A	2007	ALL	Body	Instrument Panel Cluster																																																														
A	2007	ALL	Body	Passenger Presence System																																																														
A	2007	ALL	Body	Personal Audio Link Module																																																														
A	2007	ALL	Body	Radio																																																														
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																														
A	2007	ALL	Body	Theft Deterrent Module																																																														
A	2008	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																														
A	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																														
A	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																														
A	2008	ALL	Powertrain	Transmission Control Module																																																														
A	2008	ALL	Chassis	Power Steering Control Module																																																														
A	2008	ALL	Chassis	Electronic Brake Control Module with VSES																																																														
A	2008	ALL	Chassis	Electronic Brake Control Module without VSES																																																														
A	2008	ALL	Body	Body Control Module																																																														
A	2008	ALL	Body	Digital Radio Receiver																																																														
A	2008	ALL	Body	Instrument Panel Cluster																																																														
A	2008	ALL	Body	Passenger Presence System																																																														
A	2008	ALL	Body	Personal Audio Link Module																																																														
A	2008	ALL	Body	Radio																																																														
A	2008	ALL	Body	Supplemental Inflatable Restraint																																																														
A	2008	ALL	Body	Theft Deterrent Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2009	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																														
A	2009	ALL	Powertrain	(H)2.2L L4 LAP Engine Control Module										V																																																				
A	2009	ALL	Powertrain	Transmission Control Module																																																														
A	2009	ALL	Chassis	Power Steering Control Module																																																														
A	2009	ALL	Chassis	Electronic Brake Control Module with VSES																																																														
A	2009	ALL	Chassis	Electronic Brake Control Module without VSES																																																														
A	2009	ALL	Body	Body Control Module																																																														
A	2009	ALL	Body	Digital Radio Receiver																																																														
A	2009	ALL	Body	Instrument Panel Cluster																																																														
A	2009	ALL	Body	Passenger Presence System																																																														
A	2009	ALL	Body	Personal Audio Link Module																																																														
A	2009	ALL	Body	Radio																																																														
A	2009	ALL	Body	Supplemental Inflatable Restraint																																																														
A	2009	ALL	Body	Theft Deterrent Module																																																														
A	2010	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																														
A	2010	ALL	Powertrain	(5)2.2L L4 LAP Engine Control Module										V																																																				
A	2010	ALL	Powertrain	Transmission Control Module																																																														
A	2010	ALL	Chassis	Power Steering Control Module																																																														
A	2010	ALL	Chassis	Electronic Brake Control Module with VSES																																																														
A	2010	ALL	Chassis	Electronic Brake Control Module without VSES																																																														
A	2010	ALL	Body	Body Control Module																																																														
A	2010	ALL	Body	Digital Radio Receiver																																																														
A	2010	ALL	Body	Driver Information Center																																																														
A	2010	ALL	Body	Instrument Panel Cluster																																																														
A	2010	ALL	Body	Passenger Presence System																																																														
A	2010	ALL	Body	Personal Audio Link Module																																																														
A	2010	ALL	Body	Radio																																																														
A	2010	ALL	Body	Supplemental Inflatable Restraint																																																														
A	2010	ALL	Body	Theft Deterrent Module																																																														
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																															
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																															
A	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																															
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																															
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																															
A	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																															
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																															
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																															
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																															
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																															
A	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																															
A	2012	Cobalt	Chassis	Electronic Brake Control Module																																																															
A	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																															
A	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																															
A	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																															
A	2012	Cobalt	Body	Body Control Module																																																															
A	2012	Cobalt	Body	Passenger Presence Module																																																															
A	2012	Cobalt	Body	Instrument Cluster																																																															
A	2012	Cobalt	Body	Radio																																																															
A	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																															
A	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																															
A	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
A	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																													
A	2012	Cobalt	Body	Front Seat Heating Control Module																																																													
A	2012	Cobalt	Body	Parking Assist Control Module																																																												
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
A	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
A	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
A	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
A	2013	Cobalt	Chassis	Electronic Brake Control Module																																																												
A	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2013	Cobalt	Body	Body Control Module																																																												
A	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2013	Cobalt	Body	Instrument Cluster																																																												
A	2013	Cobalt	Body	Radio																																																											
A	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																												
A	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												
A	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
A	2013	Cobalt	Body	Front Seat Heating Control Module																																																												
A	2013	Cobalt	Body	Parking Assist Control Module																																																												
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																												
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																												
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
A	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
A	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
A	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
A	2014	Cobalt	Chassis	Electronic Brake Control Module																																																												
A	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2014	Cobalt	Body	Body Control Module																																																												
A	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2014	Cobalt	Body	Instrument Cluster																																																												
A	2014	Cobalt	Body	Radio																																																											
A	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
A	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																													
A	2014	Cobalt	Body	Front Seat Heating Control Module																																																													
A	2014	Cobalt	Body	Parking Assist Control Module																																																												
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
A	2015	Cobalt	Chassis	Electronic Brake Control Module																																																												
A	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2015	Cobalt	Body	Body Control Module																																																												
A	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2015	Cobalt	Body	Instrument Cluster																																																												
A	2015	Cobalt	Body	Radio																																																											
A	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																												
A	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												
A	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
A	2015	Cobalt	Body	Front Seat Heating Control Module																																																												
A	2015	Cobalt	Body	Parking Assist Control Module																																																												
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
A	2016	Cobalt	Chassis	Electronic Brake Control Module																																																												
A	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2016	Cobalt	Body	Body Control Module																																																												
A	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2016	Cobalt	Body	Instrument Cluster																																																												
A	2016	Cobalt	Body	Radio Other																																																												
A	2016	Cobalt	Body	Radio (IOB)																																																												
A	2016	Cobalt	Body	Radio (UF7)																																																												
A	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																													
A	2016	Cobalt	Body	Front Seat Heating Control Module																																																													
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																												
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																												
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module																																																												
B	2010	Beat	Powertrain	Transmission Control Module																																																												
B	2010	Beat	Chassis	Electronic Brake Control Module																																																												
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												
B	2010	Beat	Chassis	Power Steering Control Module																																																												
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module																																																												
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
B	2010	Beat	Body	Instrument Cluster																																																												
B	2010	Beat	Body	Keyless Entry Control Module																																																												
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																												
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																												
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module																																																												
B	2011	Beat	Powertrain	Transmission Control Module																																																												
B	2011	Beat	Chassis	Electronic Brake Control Module																																																												
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												
B	2011	Beat	Chassis	Electric Power Steering Control Module																																																												
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module																																																												
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
B	2011	Beat	Body	Instrument Cluster																																																												
B	2011	Beat	Body	Keyless Entry Control Module																																																												
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module																																																												
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module																																																												
B	2012	Beat	Powertrain	Transmission Control Module																																																												
B	2012	Beat	Chassis	Electronic Brake Control Module																																																												
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												
B	2012	Beat	Chassis	Electric Power Steering Control Module																																																												
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module																																																												
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
B	2012	Beat	Body	Instrument Cluster																																																												
B	2012	Beat	Body	Keyless Entry Control Module																																																												
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module																																																												
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module																																																												
B	2013	Beat	Powertrain	Transmission Control Module																																																												
B	2013	Beat	Chassis	Electronic Brake Control Module																																																												
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												
B	2013	Beat	Chassis	Electric Power Steering Control Module																																																												
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module																																																												
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
B	2013	Beat	Body	Instrument Cluster																																																												
B	2013	Beat	Body	Keyless Entry Control Module																																																												
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module																																																												
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module																																																												
B	2014	Beat	Powertrain	Transmission Control Module																																																												
B	2014	Beat	Powertrain	Fuel Injector Control Module																																																												
B	2014	Beat	Chassis	Electronic Brake Control Module																																																												
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
B	2014	Beat	Chassis	Power Steering Control Module																																																														
B	2014	Beat	Chassis	Steering Wheel Angle Sensor Module																																																														
B	2014	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
B	2014	Beat	Body	Instrument Cluster																																																														
B	2014	Beat	Body	Telematics Communication Interface Control Module																																																														
B	2015	Beat	Powertrain	1.0L LEB Engine Control Module																																																														
B	2015	Beat	Powertrain	1.19L LC5 Engine Control Module																																																														
B	2015	Beat	Powertrain	Transmission Control Module																																																														
B	2015	Beat	Powertrain	Fuel Injector Control Module																																																														
B	2015	Beat	Chassis	Electronic Brake Control Module																																																														
B	2015	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																														
B	2015	Beat	Chassis	Power Steering Control Module																																																														
B	2015	Beat	Chassis	Steering Wheel Angle Sensor Module																																																														
B	2015	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
B	2015	Beat	Body	Instrument Cluster																																																														
B	2015	Beat	Body	Radio																																																														
B	2015	Beat	Body	Telematics Communication Interface Control Module																																																														
B	2015	Beat	Body	Keyless Entry Control Module																																																														
B	2016	Beat	Powertrain	1.0L LEB Engine Control Module																																																														
B	2016	Beat	Powertrain	1.19L LC5 Engine Control Module																																																														
B	2016	Beat	Powertrain	Transmission Control Module																																																														
B	2016	Beat	Chassis	Electronic Brake Control Module																																																														
B	2016	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																														
B	2016	Beat	Chassis	Power Steering Control Module																																																														
B	2016	Beat	Chassis	Steering Wheel Angle Sensor Module																																																														
B	2016	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
B	2016	Beat	Body	Instrument Cluster																																																														
B	2016	Beat	Body	Radio																																																														
B	2016	Beat	Body	Telematics Communication Interface Control Module																																																														
B	2016	Beat	Body	HVAC Control Module																																																														
B	2016	Beat	Body	Keyless Entry Control Module																																																														
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																														
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																														
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																														
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																														
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																														
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																														
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																														
B	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																														
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																														
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																														
B	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																														
B	2016	Cruze	Chassis	Electronic Brake Control Module																																																														
B	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																														
B	2016	Cruze	Chassis	Power Steering Control Module																																																														
B	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																														
B	2016	Cruze	Body	Body Control Module																																																														
B	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
B	2016	Cruze	Body	Passenger Presence Module																																																														
B	2016	Cruze	Body	Instrument Cluster																																																														
B	2016	Cruze	Body	Radio Controls																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
B	2016	Cruze	Body	HVAC Controls																																																													
B	2016	Cruze	Body	Trailer Interface Control Module																																																													
B	2016	Cruze	Body	Radio Base (IO3 IO7)																																																													
B	2016	Cruze	Body	Radio (IOA)																																																													
B	2016	Cruze	Body	Radio (IOB)																																																													
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																													
B	2016	Cruze	Body	Amplifier																																																													
B	2016	Cruze	Body	Multimedia Player Interface Module																																																													
B	2016	Cruze	Body	Human Machine Interface Control Module																																																													
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																													
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																													
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																													
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																													
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																													
B	2016	Cruze	Body	Keyless Entry Control Module																																																													
B	2016	Cruze	Body	Right Side Object Detection Control Module																																																													
B	2016	Cruze	Body	Left Side Object Detection Control Module																																																													
B	2016	Cruze	Body	Parking Assist Control Module																																																													
B	2016	Cruze	Body	Frontview Camera Module																																																													
B	2016	Cruze	Body	Steering Column Lock Control Module																																																													
B	2016	Cruze	Body	Long Range Radar Sensor Module																																																													
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																													
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																													
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																													
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																													
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																													
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																													
C	2010	Spark	Powertrain	Transmission Control Module																																																													
C	2010	Spark	Chassis	Electronic Brake Control Module																																																													
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																													
C	2010	Spark	Chassis	Electric Power Steering Control Module																																																													
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2010	Spark	Body	Passenger Presence Module																																																													
C	2010	Spark	Body	Instrument Cluster																																																													
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																													
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																													
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																													
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																													
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																													
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																													
C	2011	Spark	Powertrain	Transmission Control Module																																																													
C	2011	Spark	Chassis	Electronic Brake Control Module																																																													
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																													
C	2011	Spark	Chassis	Electric Power Steering Control Module																																																													
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2011	Spark	Body	Passenger Presence Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2011	Spark	Body	Instrument Cluster																																																														
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																														
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																														
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																														
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																														
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																														
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																														
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																														
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																														
C	2012	Spark	Powertrain	Transmission Control Module																																																														
C	2012	Spark	Chassis	Electronic Brake Control Module																																																														
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																														
C	2012	Spark	Chassis	Electric Power Steering Control Module																																																														
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																														
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2012	Spark	Body	Passenger Presence Module																																																															
C	2012	Spark	Body	Instrument Cluster																																																															
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																														
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																														
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																														
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																														
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																														
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																														
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																														
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																														
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																														
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																														
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																														
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																														
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																														
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																														
C	2013	Spark	Powertrain	Fuel Injector Control Module																																																														
C	2013	Spark	Chassis	Electronic Brake Control Module																																																														
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																														
C	2013	Spark	Chassis	Power Steering Control Module																																																														
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																														
C	2013	Spark	Body	Body Control Module																																																														
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2013	Spark	Body	Passenger Presence Module																																																														
C	2013	Spark	Body	Instrument Cluster																																																														
C	2013	Spark	Body	Radio																																																														
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																														
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																														
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																														
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																														
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																														
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																														
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																														
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																												
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																												
C	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
C	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
C	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																												
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
C	2014	Spark	Powertrain	Fuel Injector Control Module																																																												
C	2014	Spark	Chassis	Electronic Brake Control Module																																																												
C	2014	Spark	Chassis	Electronic Brake Control Module																																																												
C	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2014	Spark	Chassis	Power Steering Control Module																																																												
C	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2014	Spark	Body	Body Control Module																																																											
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Spark	Body	Passenger Presence Module																																																											
C	2014	Spark	Body	Instrument Cluster																																																											
C	2014	Spark	Body	Radio																																																											
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2014	Spark	Body	Keyless Entry Control Module																																																											
C	2014	Spark EV	Powertrain	Engine Control Module																																																											
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
C	2014	Spark EV	Powertrain	Drive Motor Control Module																																																											
C	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
C	2014	Spark EV	Chassis	Electronic Brake Control Module																																																											
C	2014	Spark EV	Chassis	Parking Brake Control Module																																																											
C	2014	Spark EV	Chassis	Power Steering Control Module																																																											
C	2014	Spark EV	Body	Body Control Module																																																											
C	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
C	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Spark EV	Body	Passenger Presence Module																																																											
C	2014	Spark EV	Body	Instrument Cluster																																																											
C	2014	Spark EV	Body	Radio																																																										
C	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2014	Spark EV	Body	HVAC Control Module																																																											
C	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																											
C	2014	Spark EV	Body	Coolant Heater Control Module																																																											
C	2014	Spark EV	Body	Keyless Entry Control Module																																																											
C	2014	Spark EV	Body	Battery Charger Control Module																																																											
C	2014	Spark EV	Body	DC Charging Control Module																																																											
C	2014	Spark EV	Body	Battery Energy Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																														
C	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																														
C	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																														
C	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																													
C	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																													
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																													
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																													
C	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																													
C	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																													
C	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																													
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																													
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																													
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																													
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																													
C	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																													
C	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																													
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																													
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																													
C	2015	Spark	Powertrain	Fuel Injector Control Module																																																													
C	2015	Spark	Chassis	Electronic Brake Control Module																																																													
C	2015	Spark	Chassis	Electronic Brake Control Module																																																													
C	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																													
C	2015	Spark	Chassis	Power Steering Control Module																																																													
C	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2015	Spark	Body	Body Control Module																																																													
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2015	Spark	Body	Passenger Presence Module																																																													
C	2015	Spark	Body	Instrument Cluster																																																												
C	2015	Spark	Body	Instrument Cluster																																																												
C	2015	Spark	Body	Tire Pressure Indicator Module																																																												
C	2015	Spark	Body	Radio																																																												
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2015	Spark	Body	Keyless Entry Control Module																																																												
C	2015	Spark EV	Powertrain	Engine Control Module																																																												
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																												
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																												
C	2015	Spark EV	Powertrain	Drive Motor Control Module																																																												
C	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																												
C	2015	Spark EV	Chassis	Electronic Brake Control Module																																																												
C	2015	Spark EV	Chassis	Parking Brake Control Module																																																												
C	2015	Spark EV	Chassis	Power Steering Control Module																																																												
C	2015	Spark EV	Body	Body Control Module																																																												
C	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																												
C	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Spark EV	Body	Passenger Presence Module																																																												
C	2015	Spark EV	Body	Instrument Cluster																																																												
C	2015	Spark EV	Body	Radio																																																												
C	2015	Spark EV	Body	HVAC Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																														
C	2015	Spark EV	Body	Coolant Heater Control Module																																																														
C	2015	Spark EV	Body	Keyless Entry Control Module																																																														
C	2015	Spark EV	Body	Battery Charger Control Module																																																														
C	2015	Spark EV	Body	DC Charging Control Module																																																														
C	2015	Spark EV	Body	Battery Energy Control Module																																																														
C	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																														
C	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																														
C	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																														
C	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																														
C	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																														
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																														
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																														
C	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																														
C	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																														
C	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																														
C	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																														
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																														
C	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																														
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																														
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																														
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																														
C	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																														
C	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																														
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																														
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																														
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																														
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																														
C	2016	Spark	Powertrain	Fuel Injector Control Module																																																														
C	2016	Spark	Chassis	Electronic Brake Control Module																																																														
C	2016	Spark	Chassis	Electronic Brake Control Module																																																														
C	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																														
C	2016	Spark	Chassis	Power Steering Control Module																																																														
C	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																														
C	2016	Spark	Body	Body Control Module																																																														
C	2016	Spark	Body	Body Control Module																																																														
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Spark	Body	Instrument Cluster																																																														
C	2016	Spark	Body	Instrument Cluster																																																														
C	2016	Spark	Body	Radio																																																														
C	2016	Spark	Body	Telematics Communication Interface Control Module																																																														
C	2016	Spark	Body	Keyless Entry Control Module																																																														
C	2016	Spark EV	Powertrain	Engine Control Module																																																														
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																														
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																														
C	2016	Spark EV	Powertrain	Drive Motor Control Module																																																														
C	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																														
C	2016	Spark EV	Chassis	Electronic Brake Control Module																																																														
C	2016	Spark EV	Chassis	Parking Brake Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2016	Spark EV	Chassis	Power Steering Control Module																																																													
C	2016	Spark EV	Body	Body Control Module																																																													
C	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																												
C	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Spark EV	Body	Passenger Presence Module																																																												
C	2016	Spark EV	Body	Instrument Cluster																																																												
C	2016	Spark EV	Body	Radio																																																											
C	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																											
C	2016	Spark EV	Body	HVAC Control Module																																																											
C	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																											
C	2016	Spark EV	Body	Coolant Heater Control Module																																																											
C	2016	Spark EV	Body	Keyless Entry Control Module																																																											
C	2016	Spark EV	Body	Frontview Camera Module																																																											
C	2016	Spark EV	Body	Battery Charger Control Module																																																											
C	2016	Spark EV	Body	DC Charging Control Module																																																											
C	2016	Spark EV	Body	Battery Energy Control Module																																																											
D	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
D	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
D	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
D	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
D	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2010	Spark	Powertrain	Transmission Control Module																																																											
D	2010	Spark	Chassis	Electronic Brake Control Module																																																											
D	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2010	Spark	Chassis	Electric Power Steering Control Module																																																											
D	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2010	Spark	Body	Passenger Presence Module																																																											
D	2010	Spark	Body	Instrument Cluster																																																											
D	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
D	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
D	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
D	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																											
D	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																											
D	2011	Spark	Powertrain	Transmission Control Module																																																											
D	2011	Spark	Chassis	Electronic Brake Control Module																																																											
D	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2011	Spark	Chassis	Electric Power Steering Control Module																																																											
D	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2011	Spark	Body	Passenger Presence Module																																																											
D	2011	Spark	Body	Instrument Cluster																																																											
D	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
D	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
D	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
D	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																													
D	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																													
D	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																													
D	2012	Spark	Powertrain	Transmission Control Module																																																													
D	2012	Spark	Chassis	Electronic Brake Control Module																																																												
D	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
D	2012	Spark	Chassis	Electric Power Steering Control Module																																																												
D	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2012	Spark	Body	Passenger Presence Module																																																												
D	2012	Spark	Body	Instrument Cluster																																																												
D	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
D	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												
D	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
D	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
D	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																												
D	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																												
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
D	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																												
D	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																												
D	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																												
D	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																												
D	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
D	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
D	2013	Spark	Powertrain	Fuel Injector Control Module																																																												
D	2013	Spark	Chassis	Electronic Brake Control Module																																																												
D	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
D	2013	Spark	Chassis	Power Steering Control Module																																																												
D	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
D	2013	Spark	Body	Body Control Module																																																												
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2013	Spark	Body	Passenger Presence Module																																																												
D	2013	Spark	Body	Instrument Cluster																																																												
D	2013	Spark	Body	Radio																																																												
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																												
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																												
D	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																												
D	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																												
D	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																												
D	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																												
D	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
D	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																												
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																												
D	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																												
D	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
D	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
D	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2014	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2014	Spark	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2014	Spark	Chassis	Power Steering Control Module																																																											
D	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2014	Spark	Body	Body Control Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Passenger Presence Module																																																											
D	2014	Spark	Body	Instrument Cluster																																																											
D	2014	Spark	Body	Radio																																																											
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark	Body	Keyless Entry Control Module																																																											
D	2014	Spark EV	Powertrain	Engine Control Module																																																											
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
D	2014	Spark EV	Powertrain	Drive Motor Control Module																																																											
D	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
D	2014	Spark EV	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark EV	Chassis	Parking Brake Control Module																																																											
D	2014	Spark EV	Chassis	Power Steering Control Module																																																											
D	2014	Spark EV	Body	Body Control Module																																																											
D	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
D	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark EV	Body	Passenger Presence Module																																																											
D	2014	Spark EV	Body	Instrument Cluster																																																											
D	2014	Spark EV	Body	Radio																																																										
D	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark EV	Body	HVAC Control Module																																																											
D	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																											
D	2014	Spark EV	Body	Coolant Heater Control Module																																																											
D	2014	Spark EV	Body	Keyless Entry Control Module																																																											
D	2014	Spark EV	Body	Battery Charger Control Module																																																											
D	2014	Spark EV	Body	DC Charging Control Module																																																											
D	2014	Spark EV	Body	Battery Energy Control Module																																																											
D	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
D	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
D	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																												
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																												
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																												
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																												
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
D	2015	Spark	Powertrain	Fuel Injector Control Module																																																												
D	2015	Spark	Chassis	Electronic Brake Control Module																																																												
D	2015	Spark	Chassis	Electronic Brake Control Module																																																												
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
D	2015	Spark	Chassis	Power Steering Control Module																																																												
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
D	2015	Spark	Body	Body Control Module																																																											
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark	Body	Passenger Presence Module																																																											
D	2015	Spark	Body	Instrument Cluster																																																											
D	2015	Spark	Body	Instrument Cluster																																																											
D	2015	Spark	Body	Tire Pressure Indicator Module																																																											
D	2015	Spark	Body	Radio																																																											
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2015	Spark	Body	Keyless Entry Control Module																																																											
D	2015	Spark EV	Powertrain	Engine Control Module																																																											
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
D	2015	Spark EV	Powertrain	Drive Motor Control Module																																																											
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
D	2015	Spark EV	Chassis	Electronic Brake Control Module																																																											
D	2015	Spark EV	Chassis	Parking Brake Control Module																																																											
D	2015	Spark EV	Chassis	Power Steering Control Module																																																											
D	2015	Spark EV	Body	Body Control Module																																																											
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark EV	Body	Passenger Presence Module																																																											
D	2015	Spark EV	Body	Instrument Cluster																																																											
D	2015	Spark EV	Body	Radio																																																											
D	2015	Spark EV	Body	HVAC Control Module																																																											
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																											
D	2015	Spark EV	Body	Coolant Heater Control Module																																																											
D	2015	Spark EV	Body	Keyless Entry Control Module																																																											
D	2015	Spark EV	Body	Battery Charger Control Module																																																											
D	2015	Spark EV	Body	DC Charging Control Module																																																											
D	2015	Spark EV	Body	Battery Energy Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																														
D	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																														
D	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																														
D	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																														
D	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																														
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																														
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																														
D	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																														
D	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																														
D	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																														
D	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																														
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																														
D	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																														
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																														
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																														
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																														
D	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																														
D	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																														
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																														
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																														
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																														
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																														
D	2016	Spark	Powertrain	Fuel Injector Control Module																																																														
D	2016	Spark	Chassis	Electronic Brake Control Module																																																														
D	2016	Spark	Chassis	Electronic Brake Control Module																																																														
D	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																														
D	2016	Spark	Chassis	Power Steering Control Module																																																														
D	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																														
D	2016	Spark	Body	Body Control Module																																																														
D	2016	Spark	Body	Body Control Module																																																														
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
D	2016	Spark	Body	Instrument Cluster																																																														
D	2016	Spark	Body	Instrument Cluster																																																														
D	2016	Spark	Body	Radio																																																														
D	2016	Spark	Body	Telematics Communication Interface Control Module																																																														
D	2016	Spark	Body	Keyless Entry Control Module																																																														
D	2016	Spark EV	Powertrain	Engine Control Module																																																															
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																														
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																														
D	2016	Spark EV	Powertrain	Drive Motor Control Module																																																														
D	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																														
D	2016	Spark EV	Chassis	Electronic Brake Control Module																																																														
D	2016	Spark EV	Chassis	Parking Brake Control Module																																																														
D	2016	Spark EV	Chassis	Power Steering Control Module																																																														
D	2016	Spark EV	Body	Body Control Module																																																														
D	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																														
D	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
D	2016	Spark EV	Body	Passenger Presence Module																																																														
D	2016	Spark EV	Body	Instrument Cluster																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2016	Spark EV	Body	Radio																																																														
D	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																													
D	2016	Spark EV	Body	HVAC Control Module																																																													
D	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																												
D	2016	Spark EV	Body	Coolant Heater Control Module																																																												
D	2016	Spark EV	Body	Keyless Entry Control Module																																																												
D	2016	Spark EV	Body	Frontview Camera Module																																																												
D	2016	Spark EV	Body	Battery Charger Control Module																																																												
D	2016	Spark EV	Body	DC Charging Control Module																																																												
D	2016	Spark EV	Body	Battery Energy Control Module																																																												
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Automatic Transmission																																																												
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Manual Transmission																																																												
F	2010	Camaro	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																												
F	2010	Camaro	Powertrain	(V) 3.6L LLT Transmission Control Module																																																												
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2010	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																												
F	2010	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																												
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2010	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2010	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2010	Camaro	Chassis	Power Steering Control Module																																																												
F	2010	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2010	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2010	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2010	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2010	Camaro	Body	Passenger Presence Module																																																												
F	2010	Camaro	Body	Instrument Cluster																																																												
F	2010	Camaro	Body	Auxiliary Gage Module																																																												
F	2010	Camaro	Body	Radio																																																												
F	2010	Camaro	Body	Multimedia Player Interface Module																																																												
F	2010	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																												
F	2010	Camaro	Body	Mobile Telephone Control Module																																																												
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2010	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																												
F	2010	Camaro	Body	Front Seat Heating Control Module																																																												
F	2010	Camaro	Body	Folding Top Control Module																																																												
F	2010	Camaro	Body	Parking Assist Control Module																																																												
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Automatic Transmission																																																												
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Manual Transmission																																																												
F	2011	Camaro	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																												
F	2011	Camaro	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2011	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																												
F	2011	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																													
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																													
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																													
F	2011	Camaro	Chassis	Electronic Brake Control Module																																																													
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																													
F	2011	Camaro	Chassis	Power Steering Control Module																																																												
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2011	Camaro	Body	Passenger Presence Module																																																												
F	2011	Camaro	Body	Instrument Cluster																																																												
F	2011	Camaro	Body	Head-Up Display Module																																																												
F	2011	Camaro	Body	Auxiliary Gage Module																																																												
F	2011	Camaro	Body	Headlamp Control Module																																																												
F	2011	Camaro	Body	Radio																																																											
F	2011	Camaro	Body	Multimedia Player Interface Module																																																											
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																											
F	2011	Camaro	Body	Mobile Telephone Control Module																																																											
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																										
F	2011	Camaro	Body	Front Seat Heating Control Module																																																										
F	2011	Camaro	Body	Folding Top Control Module																																																										
F	2011	Camaro	Body	Parking Assist Control Module																																																										
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																										
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																										
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																										
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module																																																										
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																										
F	2012	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2012	Camaro	Chassis	Power Steering Control Module																																																										
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2012	Camaro	Chassis	Suspension Control Module																																																										
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2012	Camaro	Body	Passenger Presence Module																																																										
F	2012	Camaro	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
F	2012	Camaro	Body	Head-Up Display Module																																																														
F	2012	Camaro	Body	Auxiliary Gage Module																																																														
F	2012	Camaro	Body	Headlamp Control Module																																																														
F	2012	Camaro	Body	Radio																																																														
F	2012	Camaro	Body	Multimedia Player Interface Module																																																														
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																														
F	2012	Camaro	Body	Mobile Telephone Control Module																																																														
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																														
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																														
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																														
F	2012	Camaro	Body	Front Seat Heating Control Module																																																														
F	2012	Camaro	Body	Folding Top Control Module																																																														
F	2012	Camaro	Body	Parking Assist Control Module																																																														
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																														
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																														
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump																																																														
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow																																																														
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																														
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																														
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump																																																														
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow																																																														
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																													
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																														
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																														
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump																																																														
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow																																																														
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																													
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																														
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																														
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump																																																														
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow																																																														
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																													
F	2013	Camaro	Chassis	Electronic Brake Control Module																																																														
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																														
F	2013	Camaro	Chassis	Power Steering Control Module																																																														
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																														
F	2013	Camaro	Chassis	Suspension Control Module																																																														
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
F	2013	Camaro	Body	Passenger Presence Module																																																														
F	2013	Camaro	Body	Instrument Cluster																																																														
F	2013	Camaro	Body	Head-Up Display Module																																																														
F	2013	Camaro	Body	Auxiliary Gage Module																																																														
F	2013	Camaro	Body	Headlamp Control Module																																																														
F	2013	Camaro	Body	Radio																																																														
F	2013	Camaro	Body	Multimedia Player Interface Module																																																														
F	2013	Camaro	Body	Mobile Telephone Control Module																																																														
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																														
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
F	2013	Camaro	Body	HVAC Control Module																																																											
F	2013	Camaro	Body	Front Seat Heating Control Module																																																											
F	2013	Camaro	Body	Folding Top Control Module																																																											
F	2013	Camaro	Body	Parking Assist Control Module																																																											
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																											
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																											
F	2014	Camaro	Powertrain	Transmission Control Module																																																											
F	2014	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2014	Camaro	Chassis	Parking Brake Control Module																																																											
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2014	Camaro	Chassis	Power Steering Control Module																																																											
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2014	Camaro	Chassis	Suspension Control Module																																																											
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2014	Camaro	Body	Passenger Presence Module																																																											
F	2014	Camaro	Body	Instrument Cluster																																																											
F	2014	Camaro	Body	Head-Up Display Module																																																											
F	2014	Camaro	Body	Auxiliary Gage Module																																																											
F	2014	Camaro	Body	Headlamp Control Module																																																											
F	2014	Camaro	Body	Radio																																																											
F	2014	Camaro	Body	Mobile Telephone Control Module																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2014	Camaro	Body	HVAC Control Module																																																											
F	2014	Camaro	Body	Front Seat Heating Control Module																																																											
F	2014	Camaro	Body	Folding Top Control Module																																																											
F	2014	Camaro	Body	Parking Assist Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2014	SS	Powertrain	Chassis Control Module																																																											
F	2014	SS	Chassis	Electronic Brake Control Module																																																											
F	2014	SS	Chassis	Parking Brake Control Module																																																											
F	2014	SS	Chassis	Power Steering Control Module																																																											
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2014	SS	Body	Body Control Module																																																											
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2014	SS	Body	Passenger Presence Module																																																											
F	2014	SS	Body	Instrument Cluster																																																											
F	2014	SS	Body	Head-Up Display Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
F	2014	SS	Body	Radio Control																																																														
F	2014	SS	Body	HVAC Control																																																														
F	2014	SS	Body	Headlamp Control Module																																																														
F	2014	SS	Body	Trailer Interface Control Module																																																														
F	2014	SS	Body	Radio																																																														
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9																																																														
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10																																																														
F	2014	SS	Body	HVAC Control Module																																																														
F	2014	SS	Body	Seat Memory Control Module - Driver																																																														
F	2014	SS	Body	Keyless Entry Control Module																																																														
F	2014	SS	Body	Right Side Object Detection Control Module																																																														
F	2014	SS	Body	Left Side Object Detection Control Module																																																														
F	2014	SS	Body	Parking Assist Control Module																																																														
F	2014	SS	Body	Frontview Camera Module																																																														
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																														
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																														
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																														
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																														
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																														
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																														
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																														
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																														
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																														
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																														
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																														
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																														
F	2015	Camaro	Powertrain	Transmission Control Module																																																														
F	2015	Camaro	Chassis	Electronic Brake Control Module																																																														
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																														
F	2015	Camaro	Chassis	Power Steering Control Module																																																														
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																														
F	2015	Camaro	Chassis	Suspension Control Module																																																														
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
F	2015	Camaro	Body	Passenger Presence Module																																																														
F	2015	Camaro	Body	Instrument Cluster																																																														
F	2015	Camaro	Body	Head-Up Display Module																																																														
F	2015	Camaro	Body	Auxiliary Gage Module																																																														
F	2015	Camaro	Body	Headlamp Control Module																																																														
F	2015	Camaro	Body	Radio																																																														
F	2015	Camaro	Body	Mobile Telephone Control Module																																																														
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6																																																														
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																														
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																														
F	2015	Camaro	Body	HVAC Control Module																																																														
F	2015	Camaro	Body	Front Seat Heating Control Module																																																														
F	2015	Camaro	Body	Folding Top Control Module																																																														
F	2015	Camaro	Body	Parking Assist Control Module																																																														
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																														
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																														
F	2015	SS	Powertrain	Fuel Injector Control Module																																																														
F	2015	SS	Powertrain	Chassis Control Module																																																														
F	2015	SS	Chassis	Electronic Brake Control Module																																																														
F	2015	SS	Chassis	Parking Brake Control Module																																																														
F	2015	SS	Chassis	Power Steering Control Module																																																														
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module																																																														
F	2015	SS	Chassis	Suspension Control Module																																																														
F	2015	SS	Body	Body Control Module																																																														
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
F	2015	SS	Body	Passenger Presence Module																																																														
F	2015	SS	Body	Instrument Cluster																																																														
F	2015	SS	Body	Head-Up Display Module																																																														
F	2015	SS	Body	Radio Control																																																														
F	2015	SS	Body	HVAC Control																																																														
F	2015	SS	Body	Headlamp Control Module																																																														
F	2015	SS	Body	Trailer Interface Control Module																																																														
F	2015	SS	Body	Radio																																																														
F	2015	SS	Body	Telematics Communication Interface Control Module																																																														
F	2015	SS	Body	HVAC Control Module																																																														
F	2015	SS	Body	Seat Memory Control Module - Driver																																																														
F	2015	SS	Body	Keyless Entry Control Module																																																														
F	2015	SS	Body	Right Side Object Detection Control Module																																																														
F	2015	SS	Body	Left Side Object Detection Control Module																																																														
F	2015	SS	Body	Parking Assist Control Module																																																														
F	2015	SS	Body	Frontview Camera Module																																																														
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																															
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																															
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																															
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																															
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																															
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																															
F	2016	Camaro	Powertrain	Transmission Control Module																																																															
F	2016	Camaro	Chassis	Electronic Brake Control Module																																																															
F	2016	Camaro	Chassis	Parking Brake Control Module																																																															
F	2016	Camaro	Chassis	Power Steering Control Module																																																															
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																															
F	2016	Camaro	Chassis	Suspension Control Module																																																															
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																															
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																															
F	2016	Camaro	Body	Serial Data Gateway Module																																																															
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
F	2016	Camaro	Body	Passenger Presence Module																																																															
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																															
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																															
F	2016	Camaro	Body	Head-Up Display Module																																																															
F	2016	Camaro	Body	Auxiliary Gage Module																																																															
F	2016	Camaro	Body	Radio Controls																																																															
F	2016	Camaro	Body	HVAC Controls																																																															
F	2016	Camaro	Body	Vehicle Performance Data Recorder																																																															
F	2016	Camaro	Body	Radio																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
F	2016	Camaro	Body	Amplifier																																																												
F	2016	Camaro	Body	Media Disc Player																																																												
F	2016	Camaro	Body	Human Machine Interface Control Module																																																												
F	2016	Camaro	Body	Navigation Control Module																																																												
F	2016	Camaro	Body	Mobile Telephone Control Module																																																												
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																												
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)																																																												
F	2016	Camaro	Body	Seat Memory Control Module - Driver																																																												
F	2016	Camaro	Body	Folding Top Control Module																																																												
F	2016	Camaro	Body	Keyless Entry Control Module																																																												
F	2016	Camaro	Body	Right Side Object Detection Control Module																																																												
F	2016	Camaro	Body	Left Side Object Detection Control Module																																																												
F	2016	Camaro	Body	Parking Assist Control Module																																																												
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2016	SS	Powertrain	Fuel Injector Control Module																																																												
F	2016	SS	Chassis	Electronic Brake Control Module																																																												
F	2016	SS	Chassis	Parking Brake Control Module																																																												
F	2016	SS	Chassis	Power Steering Control Module																																																												
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2016	SS	Chassis	Suspension Control Module																																																												
F	2016	SS	Body	Body Control Module																																																												
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2016	SS	Body	Passenger Presence Module																																																												
F	2016	SS	Body	Instrument Cluster																																																												
F	2016	SS	Body	Head-Up Display Module																																																												
F	2016	SS	Body	Radio Control																																																												
F	2016	SS	Body	HVAC Control																																																												
F	2016	SS	Body	Trailer Interface Control Module																																																												
F	2016	SS	Body	Radio																																																												
F	2016	SS	Body	Telematics Communication Interface Control Module																																																												
F	2016	SS	Body	HVAC Control Module																																																												
F	2016	SS	Body	Seat Memory Control Module - Driver																																																									V	V
F	2016	SS	Body	Keyless Entry Control Module																																																												
F	2016	SS	Body	Right Side Object Detection Control Module																																																												
F	2016	SS	Body	Left Side Object Detection Control Module																																																												
F	2016	SS	Body	Parking Assist Control Module																																																												
F	2016	SS	Body	Frontview Camera Module																																																												
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																												
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																												
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
G	2016	Malibu	Powertrain	Fuel Injector Control Module																																																												
G	2016	Malibu	Powertrain	Chassis Control Module																																																												
G	2016	Malibu	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2016	Malibu	Chassis	Parking Brake Control Module																																																															
G	2016	Malibu	Chassis	Power Steering Control Module																																																															
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																															
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																															
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																															
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
G	2016	Malibu	Body	Passenger Presence Module																																																															
G	2016	Malibu	Body	Instrument Cluster																																																															
G	2016	Malibu	Body	Headlamp Control Module																																																															
G	2016	Malibu	Body	Radio																																																															
G	2016	Malibu	Body	Digital Radio Receiver Control Module																																																															
G	2016	Malibu	Body	Multimedia Player Interface Module																																																															
G	2016	Malibu	Body	Mobile Telephone Control Module																																																															
G	2016	Malibu	Body	Telematics Communication Interface Control Module																																																															
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																															
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																															
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																															
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																															
G	2016	Malibu	Body	Seat Memory Control Module																																																															
G	2016	Malibu	Body	Front Seat Heating Control Module																																																															
G	2016	Malibu	Body	Rear Seat Heating Control Module																																																															
G	2016	Malibu	Body	Keyless Entry Control Module																																																															
G	2016	Malibu	Body	Left Side Object Detection Control Module																																																															
G	2016	Malibu	Body	Parking Assist Control Module																																																															
G	2016	Malibu	Body	Frontview Camera Module																																																															
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																															
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																															
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																															
H	2010	Sail	Powertrain	Transmission Control Module																																																															
H	2010	Sail	Chassis	Electronic Brake Control Module																																																															
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																															
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																															
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																															
H	2011	Sail	Powertrain	Transmission Control Module																																																															
H	2011	Sail	Chassis	Electronic Brake Control Module																																																															
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																															
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																															
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																															
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																															
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																															
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																															
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																															
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																															
H	2012	Sail	Powertrain	Transmission Control Module																																																															
H	2012	Sail	Chassis	Electronic Brake Control Module																																																															
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																															
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																															
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																													
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																													
H	2013	Sail	Powertrain	Transmission Control Module																																																													
H	2013	Sail	Chassis	Electronic Brake Control Module																																																													
H	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																													
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																													
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																													
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																													
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																													
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																													
H	2014	Sail	Powertrain	Transmission Control Module																																																													
H	2014	Sail	Chassis	Electronic Brake Control Module																																																													
H	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
H	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																													
H	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																													
H	2015	Sail	Chassis	Electronic Brake Control Module																																																													
H	2015	Sail	Chassis	Power Steering Control Module																																																													
H	2015	Sail	Body	Body Control Module																																																												
H	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2015	Sail	Body	Radio/HVAC Control																																																												
H	2015	Sail	Body	HVAC Control Module																																																												
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																												
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																												
H	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																												
H	2016	Sail	Chassis	Electronic Brake Control Module																																																												
H	2016	Sail	Chassis	Power Steering Control Module																																																												
H	2016	Sail	Body	Body Control Module																																																											
H	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2016	Sail	Body	Radio/HVAC Control																																																												
H	2016	Sail	Body	Radio																																																											
H	2016	Sail	Body	HVAC Control Module																																																											
J	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
J	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
J	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																												
J	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
J	2004	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																												
J	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																												
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																												
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																												
J	2004	Optra	Body	Remote Function Actuation																																																												
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel																																																												
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel Transmission Control Module																																																												
J	2004	Cavalier	Chassis	Anti-lock Brake System																																																												
J	2004	Cavalier	Body	Body Control Module																																																												
J	2004	Cavalier	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2004	Cavalier	Body	Instrument Panel Cluster																																																												
J	2004	Cavalier	Body	Radio																																																												
J	2004	Cavalier	Body	Supplemental Inflatable Restraint																																																												
J	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
J	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
J	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																												
J	2005	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																												
J	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																												
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																												
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																												
J	2005	Optra	Body	Remote Function Actuation																																																												
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
J	2005	Cavalier	Chassis	Anti-lock Brake System																																																												
J	2005	Cavalier	Body	Body Control Module																																																												
J	2005	Cavalier	Body	Digital Radio Receiver																																																												
J	2005	Cavalier	Body	Instrument Panel Cluster																																																												
J	2005	Cavalier	Body	Radio																																																												
J	2005	Cavalier	Body	Supplemental Inflatable Restraint																																																												
J	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
J	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
J	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																												
J	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
J	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
J	2006	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																												
J	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																												
J	2006	ALL	Body	Remote Function Actuation																																																												
J	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
J	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
J	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
J	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
J	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
J	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																												
J	2007	ALL	Powertrain	4 Speed Automatic																																																												
J	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
J	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																												
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																											
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																											
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																											
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																											
J	2007	ALL	Chassis	Tire Pressure Monitor																																																											
J	2007	ALL	Body	Remote Function Actuation																																																											
J	2007	ALL	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																														
J	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																														
J	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																														
J	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																														
J	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																														
J	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																														
J	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																														
J	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																																																														
J	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																														
J	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
J	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																														
J	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																														
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																														
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																														
J	2008	ALL	Chassis	Tire Pressure Monitor																																																														
J	2008	ALL	Body	Remote Function Actuation																																																														
J	2008	ALL	Body	Supplemental Inflatable Restraint																																																														
J	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																														
J	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																														
J	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																														
J	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																														
J	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																														
J	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																														
J	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																														
J	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																														
J	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
J	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																														
J	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																														
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																														
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																														
J	2009	ALL	Chassis	Tire Pressure Monitor																																																														
J	2009	ALL	Body	Remote Function Actuation																																																														
J	2009	ALL	Body	Supplemental Inflatable Restraint																																																														
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																														
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																														
J	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																														
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																														
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																														
J	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																														
J	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																														
J	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																														
J	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																														
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																														
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																														
J	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																														
J	2010	Cruze	Chassis	Electronic Brake Control Module																																																														
J	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																														
J	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																														
J	2010	Cruze	Body	Body Control Module																																																														
J	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
J	2010	Cruze	Body	Passenger Presence Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2010	Cruze	Body	Instrument Cluster																																																												
J	2010	Cruze	Body	Trailer Interface Control Module																																																												
J	2010	Cruze	Body	Radio																																																												
J	2010	Cruze	Body	Multimedia Player Interface Module																																																												
J	2010	Cruze	Body	Mobile Telephone Control Module																																																												
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																												
J	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																												
J	2010	Cruze	Body	Keyless Entry Control Module																																																												
J	2010	Cruze	Body	Parking Assist Control Module																																																												
J	2010	Cruze	Body	Steering Column Lock Control Module																																																												
J	2010	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
J	2010	Other	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																												
J	2010	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
J	2010	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																												
J	2010	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
J	2010	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
J	2010	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																												
J	2010	Other	Powertrain	Transmission Control Module 5 Speed																																																												
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control No																																																												
J	2010	Other	Chassis	Tire Pressure Monitor																																																												
J	2010	Other	Body	Remote Function Actuation																																																												
J	2010	Other	Body	Supplemental Inflatable Restraint																																																												
J	2010	Other	Body	Supplemental Inflatable Restraint																																																												
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																												
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																												
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
J	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																												
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																												
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																												
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																												
J	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																												
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																												
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																												
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																												
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																												
J	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
J	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																												
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																												
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
J	2011	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2011	Cruze	Body	Body Control Module																																					V																							
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2011	Cruze	Body	Passenger Presence Module																																																												
J	2011	Cruze	Body	Instrument Cluster																																																												
J	2011	Cruze	Body	Trailer Interface Control Module																																																												
J	2011	Cruze	Body	Radio																																																											
J	2011	Cruze	Body	Multimedia Player Interface Module																																																											
J	2011	Cruze	Body	Mobile Telephone Control Module																																																											
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
J	2011	Cruze	Body	Keyless Entry Control Module																																																											
J	2011	Cruze	Body	Parking Assist Control Module																																																											
J	2011	Cruze	Body	Steering Column Lock Control Module																																																											
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																											
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2011	Other	Powertrain	Transmission Control Module 5 Speed																																																											
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2011	Other	Chassis	Tire Pressure Monitor																																																											
J	2011	Other	Body	Remote Function Actuation																																																											
J	2011	Other	Body	Supplemental Inflatable Restraint																																																											
J	2011	Other	Body	Supplemental Inflatable Restraint																																																											
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																													
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																													
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																													
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																													
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																													
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																													
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																													
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																													
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																													
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																													
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																													
J	2012	Aveo	Powertrain	Fuel Pump Control Module																																																													
J	2012	Aveo	Powertrain	Fuel Injector Control Module																																																													
J	2012	Aveo	Chassis	Electronic Brake Control Module																																																													
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2012	Aveo	Chassis	Electric Power Steering Control Module																																																													
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2012	Aveo	Body	Body Control Module Hatchback																																																													
J	2012	Aveo	Body	Body Control Module Sedan																																																													
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2012	Aveo	Body	Passenger Presence Module																																																													
J	2012	Aveo	Body	Instrument Cluster																																																													
J	2012	Aveo	Body	Radio																																																												
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																													
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																													
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																													
J	2012	Aveo	Body	Front Seat Heating Control Module																																																													
J	2012	Aveo	Body	Parking Assist Control Module																																																													
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																													
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																													
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																													
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																													
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																													
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																													
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																													
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																													
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																													
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																													
J	2012	Cobalt	Chassis	Electronic Brake Control Module																																																													
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																													
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2012	Cobalt	Body	Body Control Module																																																													
J	2012	Cobalt	Body	Passenger Presence Module																																																													
J	2012	Cobalt	Body	Instrument Cluster																																																													
J	2012	Cobalt	Body	Radio																																																												
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																												
J	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																												
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																													
J	2012	Cobalt	Body	Front Seat Heating Control Module																																																													
J	2012	Cobalt	Body	Parking Assist Control Module																																																													
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																												
J	2012	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Cruze	Body	Body Control Module Hatchback																																						V																						
J	2012	Cruze	Body	Body Control Module Sedan																																						V																						
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2012	Cruze	Body	Passenger Presence Module																																																												
J	2012	Cruze	Body	Instrument Cluster																																																												
J	2012	Cruze	Body	Trailer Interface Control Module																																																												
J	2012	Cruze	Body	Radio																																																											
J	2012	Cruze	Body	Multimedia Player Interface Module																																																											
J	2012	Cruze	Body	Mobile Telephone Control Module																																																											
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																			V							
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																			V							
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																			V							
J	2012	Cruze	Body	Keyless Entry Control Module																																																											
J	2012	Cruze	Body	Parking Assist Control Module																																																											
J	2012	Cruze	Body	Steering Column Lock Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																											
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																											
J	2012	Sonic (First Gen)	Body	Remote Function Actuation																																																											
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																											
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																											
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module Chassis Expansion CAN BUS																																																												
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module High Speed CAN Bus																																																											
J	2012	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																											
J	2012	Sonic (Second Gen)	Body	Body Control Module Sedan																																																											
J	2012	Sonic (Second Gen)	Body	Passenger Presence Module																																																											
J	2012	Sonic (Second Gen)	Body	Instrument Cluster																																																											
J	2012	Sonic (Second Gen)	Body	Radio																																																											
J	2012	Sonic (Second Gen)	Body	Telematic Vehicle Localization and Immobilization Control Module																																																											
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																											
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																											
J	2012	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																											
J	2012	Sonic (Second Gen)	Body	Parking Assist Control Module																																																											
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
J	2013	Aveo	Powertrain	Fuel Pump Control Module																																																											
J	2013	Aveo	Powertrain	Fuel Injector Control Module																																																											
J	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
J	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2013	Aveo	Chassis	Electric Power Steering Control Module																																																											
J	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2013	Aveo	Body	Body Control Module Hatchback																																																											
J	2013	Aveo	Body	Body Control Module Sedan																																																											
J	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2013	Aveo	Body	Passenger Presence Module																																																											
J	2013	Aveo	Body	Instrument Cluster																																																											
J	2013	Aveo	Body	Radio																																																											
J	2013	Aveo	Body	Telematics Communication Interface Control Module																																																											
J	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
J	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
J	2013	Aveo	Body	Front Seat Heating Control Module																																																											
J	2013	Aveo	Body	Parking Assist Control Module																																																											
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																													
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																													
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																													
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																													
J	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																													
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																													
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																													
J	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																													
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																													
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																													
J	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																													
J	2013	Cobalt	Chassis	Electronic Brake Control Module																																																													
J	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2013	Cobalt	Body	Body Control Module																																																													
J	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2013	Cobalt	Body	Instrument Cluster																																																													
J	2013	Cobalt	Body	Radio																																																												
J	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																													
J	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																													
J	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																													
J	2013	Cobalt	Body	Front Seat Heating Control Module																																																													
J	2013	Cobalt	Body	Parking Assist Control Module																																																													
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																													
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																													
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																													
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																													
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																													
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
J	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																													
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																													
J	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																													
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																													
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																													
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																													
J	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																													
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																													
J	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																													
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																													
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																													
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																													
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																													
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																													
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																													
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																													
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																													
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																													
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																													
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																													
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																													
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																													
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																													
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																													
J	2013	Cruze	Chassis	Electronic Brake Control Module																																																													
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2013	Cruze	Body	Body Control Module Hatchback																																						V																							
J	2013	Cruze	Body	Body Control Module Sedan																																						V																							
J	2013	Cruze	Body	Body Control Module Station Wagon																																						V																							
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2013	Cruze	Body	Passenger Presence Module																																																													
J	2013	Cruze	Body	Instrument Cluster																																																													
J	2013	Cruze	Body	Trailer Interface Control Module																																																													
J	2013	Cruze	Body	Radio																																																												
J	2013	Cruze	Body	Digital Radio Receiver Control Module																																																												
J	2013	Cruze	Body	Multimedia Player Interface Module																																																												
J	2013	Cruze	Body	Mobile Telephone Control Module																																																												
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																		V									
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																												
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																		V									
J	2013	Cruze	Body	Front Seat Heating Control Module																																																												
J	2013	Cruze	Body	Keyless Entry Control Module																																																												
J	2013	Cruze	Body	Right Side Object Detection Control Module																																																												
J	2013	Cruze	Body	Left Side Object Detection Control Module																																																												
J	2013	Cruze	Body	Parking Assist Control Module																																																												
J	2013	Cruze	Body	Steering Column Lock Control Module																																																												
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																												
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																												
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																												
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																												
J	2013	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																												
J	2013	Sonic (First Gen)	Body	Remote Function Actuation																																																												
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																												
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Fuel Pump Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Fuel Pump Control Module																																																												
J	2013	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																												
J	2013	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2013	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2013	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																												
J	2013	Sonic (Second Gen)	Body	Body Control Module Sedan																																																												
J	2013	Sonic (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2013	Sonic (Second Gen)	Body	Passenger Presence Module																																																												
J	2013	Sonic (Second Gen)	Body	Instrument Cluster																																																												
J	2013	Sonic (Second Gen)	Body	Radio																																																												
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																												
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																													
J	2013	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																													
J	2013	Sonic (Second Gen)	Body	Parking Assist Control Module																																																													
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																													
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																													
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																													
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																													
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																													
J	2013	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																													
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																													
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																													
J	2013	Spin	Powertrain	1.8L LMD Transmission Control Module																																																													
J	2013	Spin	Chassis	Electronic Brake Control Module																																																													
J	2013	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2013	Spin	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2013	Spin	Body	Body Control Module																																																													
J	2013	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2013	Spin	Body	Instrument Cluster																																																													
J	2013	Spin	Body	Radio																																																												
J	2013	Spin	Body	HVAC Control Module Heater Only (C41)																																																													
J	2013	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2013	Spin	Body	HVAC Control Module Single Zone (C60)																																																													
J	2013	Spin	Body	Parking Assist Control Module																																																													
J	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																													
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																													
J	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																													
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																													
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																													
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																													
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																													
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
J	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																													
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																													
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																													
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																													
J	2014	Aveo	Powertrain	Chassis Control Module																																																														
J	2014	Aveo	Powertrain	Fuel Injector Control Module																																																													
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																													
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																													
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2014	Aveo	Chassis	Power Steering Control Module																																																													
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2014	Aveo	Body	Body Control Module Hatchback																																																													
J	2014	Aveo	Body	Body Control Module Sedan																																																													
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2014	Aveo	Body	Instrument Cluster																																																													
J	2014	Aveo	Body	Radio																																																													
J	2014	Aveo	Body	Telematics Communication Interface Control Module																																																													
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																													
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																													
J	2014	Aveo	Body	Front Seat Heating Control Module																																																													
J	2014	Aveo	Body	Keyless Entry Control Module																																																													
J	2014	Aveo	Body	Parking Assist Control Module																																																													
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																													
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																													
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																													
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																													
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																													
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																													
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																													
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																													
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																													
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																													
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																													
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																													
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																													
J	2014	Cobalt	Chassis	Electronic Brake Control Module																																																													
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2014	Cobalt	Body	Body Control Module																																																													
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2014	Cobalt	Body	Instrument Cluster																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2014	Cobalt	Body	Radio																																																												
J	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Cobalt	Body	Front Seat Heating Control Module																																																												
J	2014	Cobalt	Body	Parking Assist Control Module																																																												
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																											
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																											
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																											
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																											
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																											
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																											
J	2014	Cruze	Powertrain	Fuel Injector Control Module																																																											
J	2014	Cruze	Chassis	Electronic Brake Control Module																																																											
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2014	Cruze	Chassis	Power Steering Control Module																																																											
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2014	Cruze	Body	Body Control Module Hatchback																																						V																				
J	2014	Cruze	Body	Body Control Module Sedan																																						V																				
J	2014	Cruze	Body	Body Control Module Station Wagon																																						V																				
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2014	Cruze	Body	Passenger Presence Module																																																											
J	2014	Cruze	Body	Instrument Cluster																																																											
J	2014	Cruze	Body	Trailer Interface Control Module																																																											
J	2014	Cruze	Body	Radio																																																										
J	2014	Cruze	Body	Digital Radio Receiver Control Module																																																											
J	2014	Cruze	Body	Multimedia Player Interface Module																																																											
J	2014	Cruze	Body	Mobile Telephone Control Module																																																											
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																											
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																											
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																											
J	2014	Cruze	Body	Front Seat Heating Control Module																																																											
J	2014	Cruze	Body	Keyless Entry Control Module																																																											
J	2014	Cruze	Body	Right Side Object Detection Control Module																																																											
J	2014	Cruze	Body	Left Side Object Detection Control Module																																																											
J	2014	Cruze	Body	Parking Assist Control Module																																																											
J	2014	Cruze	Body	Steering Column Lock Control Module																																																											
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module																																																											
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2014	Sonic	Powertrain	1.4L LDD Chassis Control Module																																																												
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.4L LUJ Chassis Control Module																																																												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Chassis Control Module																																																												
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(C) 1.6L LDE Chassis Control Module																																																												
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.6L LED Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(H) 1.8L LUW Chassis Control Module																																																												
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(G) 1.8L LWE Chassis Control Module																																																												
J	2014	Sonic	Powertrain	Fuel Injector Control Module																																																												
J	2014	Sonic	Chassis	Electronic Brake Control Module																																																												
J	2014	Sonic	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2014	Sonic	Chassis	Power Steering Control Module																																																												
J	2014	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Sonic	Body	Body Control Module Hatchback																																																												
J	2014	Sonic	Body	Body Control Module Sedan																																																												
J	2014	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Sonic	Body	Passenger Presence Module																																																												
J	2014	Sonic	Body	Instrument Cluster																																																												
J	2014	Sonic	Body	Radio																																																											
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2014	Sonic	Body	HVAC Control Module Heater Only (C41)																																																											
J	2014	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2014	Sonic	Body	HVAC Control Module Single Zone (C60)																																																											
J	2014	Sonic	Body	Front Seat Heating Control Module																																																											
J	2014	Sonic	Body	Parking Assist Control Module																																																											
J	2014	Sonic	Body	Frontview Camera Module																																																											
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																													
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																													
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																													
J	2014	Spin	Powertrain	1.5L L2B Transmission Control Module																																																													
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Automatic Transmission																																																													
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Manual Transmission																																																													
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																													
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																													
J	2014	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																													
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																													
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																													
J	2014	Spin	Powertrain	1.8L LMD Transmission Control Module																																																													
J	2014	Spin	Chassis	Electronic Brake Control Module																																																													
J	2014	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2014	Spin	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2014	Spin	Body	Body Control Module																																																													
J	2014	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2014	Spin	Body	Instrument Cluster																																																													
J	2014	Spin	Body	Radio																																																												
J	2014	Spin	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Spin	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Spin	Body	Parking Assist Control Module																																																												
J	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																												
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
J	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																												
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																												
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
J	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																															
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																															
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																															
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																															
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																															
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																															
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																															
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																															
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																															
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																															
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																															
J	2015	Aveo	Powertrain	Chassis Control Module																																																															
J	2015	Aveo	Powertrain	Fuel Injector Control Module																																																															
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																															
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																															
J	2015	Aveo	Chassis	Power Steering Control Module																																																															
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																															
J	2015	Aveo	Body	Body Control Module Hatchback																																																															
J	2015	Aveo	Body	Body Control Module Sedan																																																															
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
J	2015	Aveo	Body	Instrument Cluster																																																															
J	2015	Aveo	Body	Radio																																																															
J	2015	Aveo	Body	Telematics Communication Interface Control Module																																																															
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																															
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																															
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																															
J	2015	Aveo	Body	Front Seat Heating Control Module																																																															
J	2015	Aveo	Body	Keyless Entry Control Module																																																															
J	2015	Aveo	Body	Parking Assist Control Module																																																															
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																															
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																															
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																															
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																															
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																															
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																															
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																															
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																															
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																															
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																															
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																															
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																															
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																															
J	2015	Cobalt	Chassis	Electronic Brake Control Module																																																															
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																															
J	2015	Cobalt	Body	Body Control Module																																																															
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
J	2015	Cobalt	Body	Instrument Cluster																																																															
J	2015	Cobalt	Body	Radio																																																															
J	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																															
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																													
J	2015	Cobalt	Body	Front Seat Heating Control Module																																																													
J	2015	Cobalt	Body	Parking Assist Control Module																																																													
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																													
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																													
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
J	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																													
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																													
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																													
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
J	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																													
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																													
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																													
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																													
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																													
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																													
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
J	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																													
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																													
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																													
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																													
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
J	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																													
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																													
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																													
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
J	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																													
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
J	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																													
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																													
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																													
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																													
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																														
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																													
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																													
J	2015	Cruze	Powertrain	Fuel Injector Control Module																																																														
J	2015	Cruze	Chassis	Electronic Brake Control Module																																																													
J	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2015	Cruze	Chassis	Power Steering Control Module																																																													
J	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2015	Cruze	Body	Body Control Module Hatchback																																						V																						
J	2015	Cruze	Body	Body Control Module Sedan																																						V																						
J	2015	Cruze	Body	Body Control Module Station Wagon																																						V																						
J	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2015	Cruze	Body	Passenger Presence Module																																																													
J	2015	Cruze	Body	Instrument Cluster																																																													
J	2015	Cruze	Body	Trailer Interface Control Module																																																													
J	2015	Cruze	Body	Radio																																																												
J	2015	Cruze	Body	Digital Radio Receiver Control Module																																																												
J	2015	Cruze	Body	Multimedia Player Interface Module																																																												
J	2015	Cruze	Body	Mobile Telephone Control Module																																																												
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																		V									
J	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																												
J	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																		V									
J	2015	Cruze	Body	Front Seat Heating Control Module																																																												
J	2015	Cruze	Body	Keyless Entry Control Module																																																												
J	2015	Cruze	Body	Right Side Object Detection Control Module																																																												
J	2015	Cruze	Body	Left Side Object Detection Control Module																																																												
J	2015	Cruze	Body	Parking Assist Control Module																																																												
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2015	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																														
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																														
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																														
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																														
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	1.6L LED Transmission Control Module																																																														
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																														
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																														
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																														
J	2015	Sonic	Powertrain	Chassis Control Module																																																														
J	2015	Sonic	Powertrain	Fuel Injector Control Module																																																														
J	2015	Sonic	Chassis	Electronic Brake Control Module																																																														
J	2015	Sonic	Chassis	Power Steering Control Module																																																														
J	2015	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																														
J	2015	Sonic	Body	Body Control Module Hatchback																																																														
J	2015	Sonic	Body	Body Control Module Sedan																																																														
J	2015	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
J	2015	Sonic	Body	Passenger Presence Module																																																														
J	2015	Sonic	Body	Instrument Cluster																																																														
J	2015	Sonic	Body	Radio																																																														
J	2015	Sonic	Body	Telematics Communication Interface Control Module																																																														
J	2015	Sonic	Body	HVAC Control Module Heater Only (C41)																																																														
J	2015	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
J	2015	Sonic	Body	HVAC Control Module Single Zone (C60)																																																														
J	2015	Sonic	Body	Front Seat Heating Control Module																																																														
J	2015	Sonic	Body	Parking Assist Control Module																																																														
J	2015	Sonic	Body	Frontview Camera Module																																																														
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																														
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																														
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																														
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																														
J	2015	Spin	Powertrain	1.5L L2B Transmission Control Module																																																														
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																													
J	2015	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																													
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																													
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																													
J	2015	Spin	Powertrain	1.8L LMD Transmission Control Module																																																													
J	2015	Spin	Chassis	Electronic Brake Control Module																																																													
J	2015	Spin	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2015	Spin	Body	Body Control Module																																																												
J	2015	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2015	Spin	Body	Instrument Cluster																																																													
J	2015	Spin	Body	Radio																																																												
J	2015	Spin	Body	Telematics Communication Interface Control Module																																																												
J	2015	Spin	Body	HVAC Control Module Heater Only (C41)																																																												
J	2015	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2015	Spin	Body	HVAC Control Module Single Zone (C60)																																																												
J	2015	Spin	Body	Front Seat Heating Control Module																																																												
J	2015	Spin	Body	Parking Assist Control Module																																																												
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
J	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
J	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
J	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
J	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2016	Aveo	Powertrain	Chassis Control Module																																																													
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | New Actuator Setup Procedure | VSCM Data | Signal Data | VSCM Disable Reason | VSCM Power Steering Reset | Range Measurements | Module Data | Inhibit Data | Calibrate Module | Exh. Aftertreatment Data | Parking Brake Shoe Service Reset | Parking Brake Actuator DTC Reset | Parking Brake Switch Procedure | Charging Info | RVS Disable 1 History | RVS Disable 2 History | RVS Disable 3 History | RVS Disable 4 History | RVS Disable 5 History | RVS Disable 6 History | RVS Disable 7 History | Passenger presence system learn | Signal Type | Module ID Information | Open History Data | Close History Data | Last Open Fail Data | Last Close Fail Data | Obstacle Detect Opening Data | Obstacle Detect Closing Data | LGM Open/Close Test | Deployment Loop 1-14 Resistance | Deployment Loop 15-18 Resistance | Deployment Loop Configuration | Sensor Configuration | Parking Brake Calibration | CAN Bus Communication | Remote Vehicle Start Data | Remote Vehicle Start Disable History 1 Data | Remote Vehicle Start Disable History 2 Data | Remote Vehicle Start Disable History 3 Data | Remote Vehicle Start Disable History 4 Data | Remote Vehicle Start Disable History 5 Data | Remote Vehicle Start Disable History 6 Data | Remote Vehicle Start Disable History 7 Data | Steering Wheel Control Switches | Vehicle Access | Passenger Presence Data | HVAC Door Position Data | A/C Permission Data | Last Liftgate Close Malfunction Data | Last Liftgate Open Malfunction Data | Engineering Data 1 | Engineering Data 2 | Seat Position Data | Steering Column Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																													
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																													
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																													
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																													
J	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																													
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																													
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																													
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																													
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																													
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																													
J	2016	Cruze	Powertrain	Fuel Injector Control Module																																																													
J	2016	Cruze	Powertrain	Chassis Control Module																																																													
J	2016	Cruze	Chassis	Electronic Brake Control Module																																																													
J	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2016	Cruze	Chassis	Power Steering Control Module																																																													
J	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2016	Cruze	Body	Body Control Module Hatchback																																																													
J	2016	Cruze	Body	Body Control Module Sedan																																																													
J	2016	Cruze	Body	Body Control Module Station Wagon																																																													
J	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2016	Cruze	Body	Passenger Presence Module																																																													
J	2016	Cruze	Body	Instrument Cluster																																																													
J	2016	Cruze	Body	Trailer Interface Control Module																																																													
J	2016	Cruze	Body	Radio Other																																																													
J	2016	Cruze	Body	Radio (UF7)																																																													
J	2016	Cruze	Body	Multimedia Player Interface Module																																																													
J	2016	Cruze	Body	Mobile Telephone Control Module																																																													
J	2016	Cruze	Body	Telematics Communication Interface Control Module																																																													
J	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
J	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																													
J	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																													
J	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																													
J	2016	Cruze	Body	Front Seat Heating Control Module																																																													
J	2016	Cruze	Body	Keyless Entry Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2016	Cruze	Body	Right Side Object Detection Control Module																																																														
J	2016	Cruze	Body	Left Side Object Detection Control Module																																																														
J	2016	Cruze	Body	Parking Assist Control Module																																																														
J	2016	Cruze	Body	Steering Column Lock Control Module																																																														
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																														
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																														
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																														
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																														
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module																																																														
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																														
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																														
J	2016	Sonic	Powertrain	Chassis Control Module																																																														
J	2016	Sonic	Powertrain	Fuel Injector Control Module																																																														
J	2016	Sonic	Chassis	Electronic Brake Control Module																																																														
J	2016	Sonic	Chassis	Power Steering Control Module																																																														
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																														
J	2016	Sonic	Body	Body Control Module Hatchback																																																														
J	2016	Sonic	Body	Body Control Module Sedan																																																														
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
J	2016	Sonic	Body	Passenger Presence Module																																																														
J	2016	Sonic	Body	Instrument Cluster																																																														
J	2016	Sonic	Body	Radio Other																																																														
J	2016	Sonic	Body	Radio (UF7)																																																														
J	2016	Sonic	Body	Radio (UH7)																																																														
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7																																																														
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																														
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)																																																														
J	2016	Sonic	Body	Front Seat Heating Control Module																																																														
J	2016	Sonic	Body	Parking Assist Control Module																																																														
J	2016	Sonic	Body	Frontview Camera Module																																																														
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																														
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																														
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																														
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																														
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module																																																														
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																														
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																														
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																														
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																														
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																														
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module																																																														
J	2016	Spin	Chassis	Electronic Brake Control Module																																																														
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module																																																														
J	2016	Spin	Body	Body Control Module																																																														
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
J	2016	Spin	Body	Instrument Cluster																																																														
J	2016	Spin	Body	Radio																																																														
J	2016	Spin	Body	Telematics Communication Interface Control Module																																																														
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)																																																														
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)																																																														
J	2016	Spin	Body	Front Seat Heating Control Module																																																														
J	2016	Spin	Body	Parking Assist Control Module																																																														
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																														
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																														
K	2006	ALL	Powertrain	Transmission Control Module																																																														
K	2006	ALL	Chassis	Electronic Brake Control Module																																																														
K	2006	ALL	Body	Remote Function Actuation																																																														
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																														
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																														
K	2007	ALL	Powertrain	Transmission Control Module																																																														
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module																																																														
K	2007	ALL	Chassis	Teves Electronic Brake Control Module																																																														
K	2007	ALL	Body	Remote Function Actuation																																																														
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																														
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																														
K	2008	ALL	Powertrain	Transmission Control Module																																																														
K	2008	ALL	Chassis	Electronic Brake Control Module																																																														
K	2008	ALL	Body	Remote Function Actuation																																																														
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																														
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																														
K	2009	ALL	Powertrain	Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2009	ALL	Chassis	Electronic Brake Control Module																																																														
K	2009	ALL	Body	Remote Function Actuation																																																														
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																													
K	2010	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																													
K	2010	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																													
K	2010	ALL	Powertrain	Transmission Control Module																																																													
K	2010	ALL	Chassis	Electronic Brake Control Module																																																													
K	2010	ALL	Body	Remote Function Actuation																																																													
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																													
K	2011	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																													
K	2011	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																													
K	2011	ALL	Powertrain	Transmission Control Module																																																													
K	2011	ALL	Chassis	Electronic Brake Control Module																																																													
K	2011	ALL	Body	Remote Function Actuation																																																													
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																													
K	2012	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																													
K	2012	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																													
K	2012	ALL	Powertrain	Transmission Control Module																																																													
K	2012	ALL	Chassis	Electronic Brake Control Module																																																													
K	2012	ALL	Body	Remote Function Actuation																																																													
K	2012	ALL	Body	Supplemental Inflatable Restraint																																																													
K	2013	Onix	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																													
K	2013	Onix	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																													
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																													
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																													
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																													
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																													
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																													
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																													
K	2013	Onix	Powertrain	Transmission Control Module																																																													
K	2013	Onix	Powertrain	Transmission Control Module																																																													
K	2013	Onix	Chassis	Electronic Brake Control Module																																																													
K	2013	Onix	Chassis	Electronic Brake Control Module																																																													
K	2013	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																													
K	2013	Onix	Chassis	Steering Wheel Angle Sensor Module																																																													
K	2013	Onix	Body	Body Control Module																																																													
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
K	2013	Onix	Body	Instrument Cluster																																																													
K	2013	Onix	Body	Radio																																																													
K	2013	Onix	Body	Parking Assist Control Module																																																													
K	2013	Onix	Body	Remote Function Actuation																																																													
K	2013	Prisma	Powertrain	Engine Control Module																																																													
K	2013	Prisma	Powertrain	Transmission Control Module																																																													
K	2013	Prisma	Chassis	Electronic Brake Control Module																																																													
K	2013	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																													
K	2013	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																													
K	2013	Prisma	Body	Body Control Module																																																													
K	2013	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
K	2013	Prisma	Body	Instrument Cluster																																																													
K	2013	Prisma	Body	Radio																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2013	Prisma	Body	Parking Assist Control Module																																																														
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																														
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																														
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																														
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																														
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																														
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																														
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																														
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module																																																														
K	2014	Onix	Chassis	Electronic Brake Control Module																																																														
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																														
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module																																																														
K	2014	Onix	Body	Body Control Module																																																														
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
K	2014	Onix	Body	Instrument Cluster																																																														
K	2014	Onix	Body	Radio																																																														
K	2014	Onix	Body	Parking Assist Control Module																																																														
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																														
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																														
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module																																																														
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																														
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																														
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																														
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																														
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																														
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																														
K	2014	Prisma	Chassis	Electronic Brake Control Module																																																														
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																														
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																														
K	2014	Prisma	Body	Body Control Module																																																														
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
K	2014	Prisma	Body	Instrument Cluster																																																														
K	2014	Prisma	Body	Radio																																																														
K	2014	Prisma	Body	Parking Assist Control Module																																																														
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																														
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																														
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																														
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																														
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																														
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																														
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																														
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module																																																														
K	2015	Onix	Chassis	Electronic Brake Control Module																																																														
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module																																																														
K	2015	Onix	Body	Body Control Module																																																														
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
K	2015	Onix	Body	Instrument Cluster																																																														
K	2015	Onix	Body	Radio																																																														
K	2015	Onix	Body	Parking Assist Control Module																																																														
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																														
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																												
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																												
K	2015	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																												
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																												
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																												
K	2015	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																												
K	2015	Prisma	Chassis	Electronic Brake Control Module																																																												
K	2015	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Prisma	Body	Body Control Module																																																												
K	2015	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Prisma	Body	Instrument Cluster																																																												
K	2015	Prisma	Body	Radio																																																												
K	2015	Prisma	Body	Parking Assist Control Module																																																												
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																												
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																												
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																												
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																												
K	2016	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																												
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																												
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																												
K	2016	Onix	Powertrain	1.4L LKK Transmission Control Module																																																												
K	2016	Onix	Chassis	Electronic Brake Control Module																																																												
K	2016	Onix	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2016	Onix	Body	Body Control Module																																																												
K	2016	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2016	Onix	Body	Instrument Cluster																																																												
K	2016	Onix	Body	Radio																																																												
K	2016	Onix	Body	Parking Assist Control Module																																																												
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																												
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																												
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																												
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																												
K	2016	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																												
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																												
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																												
K	2016	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																												
K	2016	Prisma	Chassis	Electronic Brake Control Module																																																												
K	2016	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2016	Prisma	Body	Body Control Module																																																												
K	2016	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2016	Prisma	Body	Instrument Cluster																																																												
K	2016	Prisma	Body	Radio																																																												
K	2016	Prisma	Body	HVAC Control Module																																																												
K	2016	Prisma	Body	Front Seat Heating Control Module																																																												
K	2016	Prisma	Body	Parking Assist Control Module																																																												
L	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
L	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
L	2004	ALL	Powertrain	Transmission Control Module																																																												
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																											
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																												
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
L	2004	ALL	Body	ISU																																																														
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																															
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																															
L	2005	ALL	Powertrain	Transmission Control Module																																																															
L	2005	ALL	Chassis	Anti-lock Brake System																																																															
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2005	ALL	Body	ISU																																																															
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																															
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																															
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																															
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																															
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																															
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2006	ALL	Body	ISU																																																															
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																															
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																															
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module										V																																																				
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																															
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																															
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector																																																															
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																															
L	2007	ALL	Chassis	Electronic Brake Control Module																																																															
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2007	ALL	Body	ISU																																																															
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																															
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module										V																																																				
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																															
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																															
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																															
L	2008	ALL	Chassis	Electronic Brake Control Module																																																															
L	2008	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2008	ALL	Body	ISU																																																															
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																															
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module										V																																																				
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																															
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																															
L	2009	ALL	Chassis	Electronic Brake Control Module																																																															
L	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2009	ALL	Body	ISU																																																															
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																															
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																															
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module										V																																																				
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																															
L	2010	ALL	Chassis	Electronic Brake Control Module																																																															
L	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2010	ALL	Body	ISU																																																															
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																															
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module										V																																																			
L	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																													
L	2011	ALL	Chassis	Electronic Brake Control Module																																																													
L	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
L	2011	ALL	Body	ISU																																																												
M	2004	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2004	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2004	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2004	ALL	Chassis	Anti-lock Brake System																																																												
M	2004	ALL	Body	Remote Function Actuation																																																												
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2005	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2005	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2005	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2005	ALL	Chassis	Anti-lock Brake System																																																												
M	2005	ALL	Body	Remote Function Actuation																																																												
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2006	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2006	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2006	ALL	Chassis	Anti-lock Brake System																																																												
M	2006	ALL	Body	Remote Function Actuation																																																												
M	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2007	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2007	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2007	ALL	Chassis	Anti-lock Brake System																																																												
M	2007	ALL	Body	Remote Function Actuation																																																												
M	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2008	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2008	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2008	ALL	Chassis	Anti-lock Brake System																																																												
M	2008	ALL	Body	Remote Function Actuation																																																												
M	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2009	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2009	ALL	Chassis	Anti-lock Brake System																																																												
M	2009	ALL	Body	Remote Function Actuation																																																												
M	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
M	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
M	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
M	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
M	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
M	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
M	2010	Spark	Powertrain	Transmission Control Module																																																												
M	2010	Spark	Chassis	Electronic Brake Control Module																																																												
M	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
M	2010	Spark	Chassis	Electric Power Steering Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
M	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																														
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2010	Spark	Body	Passenger Presence Module																																																														
M	2010	Spark	Body	Instrument Cluster																																																													
M	2011	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																													
M	2011	Caprice	Powertrain	Transmission Control Module																																																													
M	2011	Caprice	Powertrain	Fuel Pump Control Module																																																													
M	2011	Caprice	Chassis	Electronic Brake Control Module																																																													
M	2011	Caprice	Body	Body Control Module														V	V	V	V	V	V	V	V																																								
M	2011	Caprice	Body	HVAC Control Module																																																													
M	2011	Caprice	Body	Instrument Panel Cluster																																																													
M	2011	Caprice	Body	Passenger Presence System																																																													
M	2011	Caprice	Body	Radio																																																													
M	2011	Caprice	Body	Remote Control Door Lock Receiver																																																													
M	2011	Caprice	Body	Supplemental Inflatable Restraint																																																													
M	2011	Caprice	Body	Theft Deterrent Module																																																													
M	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																													
M	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																													
M	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																													
M	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																													
M	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																													
M	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																													
M	2011	Spark	Powertrain	Transmission Control Module																																																													
M	2011	Spark	Chassis	Electronic Brake Control Module																																																													
M	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																													
M	2011	Spark	Chassis	Electric Power Steering Control Module																																																													
M	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																													
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2011	Spark	Body	Passenger Presence Module																																																													
M	2011	Spark	Body	Instrument Cluster																																																													
M	2012	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module										V																																																		
M	2012	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																													
M	2012	Caprice	Powertrain	Transmission Control Module																																																													
M	2012	Caprice	Powertrain	Fuel Pump Control Module																																																													
M	2012	Caprice	Chassis	Electronic Brake Control Module																																																													
M	2012	Caprice	Body	Body Control Module														V	V	V	V	V	V	V	V																																								
M	2012	Caprice	Body	HVAC Control Module																																																													
M	2012	Caprice	Body	Instrument Panel Cluster																																																													
M	2012	Caprice	Body	Passenger Presence System																																																													
M	2012	Caprice	Body	Radio																																																													
M	2012	Caprice	Body	Remote Control Door Lock Receiver																																																													
M	2012	Caprice	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
M	2012	Caprice	Body	Theft Deterrent Module																																																													
M	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																													
M	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																													
M	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
M	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
M	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																												
M	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
M	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																												
M	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																												
M	2012	Spark	Powertrain	Transmission Control Module																																																												
M	2012	Spark	Chassis	Electronic Brake Control Module																																																												
M	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
M	2012	Spark	Chassis	Electric Power Steering Control Module																																																												
M	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2012	Spark	Body	Passenger Presence Module																																																												
M	2012	Spark	Body	Instrument Cluster																																																												
M	2013	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module										V																																																		
M	2013	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																												
M	2013	Caprice	Powertrain	Transmission Control Module																																																												
M	2013	Caprice	Powertrain	Fuel Pump Control Module																																																												
M	2013	Caprice	Chassis	Electronic Brake Control Module																																																												
M	2013	Caprice	Body	Body Control Module														V	V	V	V	V	V	V	V																																							
M	2013	Caprice	Body	HVAC Control Module																																																												
M	2013	Caprice	Body	Instrument Panel Cluster																																																												
M	2013	Caprice	Body	Passenger Presence System																																																												
M	2013	Caprice	Body	Radio																																																												
M	2013	Caprice	Body	Remote Control Door Lock Receiver																																																												
M	2013	Caprice	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
M	2013	Caprice	Body	Theft Deterrent Module																																																												
M	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
M	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												
M	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
M	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
M	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																												
M	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																												
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
M	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																												
M	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																												
M	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																												
M	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																												
M	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
M	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
M	2013	Spark	Powertrain	Fuel Injector Control Module																																																												
M	2013	Spark	Chassis	Electronic Brake Control Module																																																												
M	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
M	2013	Spark	Chassis	Power Steering Control Module																																																												
M	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
M	2013	Spark	Body	Body Control Module																																																												
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2013	Spark	Body	Passenger Presence Module																																																												
M	2013	Spark	Body	Instrument Cluster																																																												
M	2013	Spark	Body	Radio																																																												
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																												
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
M	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																														
M	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																														
M	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																														
M	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																													
M	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																													
M	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																													
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																													
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																													
M	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																													
M	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																													
M	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																													
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																													
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																													
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																													
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																													
M	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																													
M	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																													
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																													
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																													
M	2014	Spark	Powertrain	Fuel Injector Control Module																																																													
M	2014	Spark	Chassis	Electronic Brake Control Module																																																													
M	2014	Spark	Chassis	Electronic Brake Control Module																																																													
M	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																													
M	2014	Spark	Chassis	Power Steering Control Module																																																													
M	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																													
M	2014	Spark	Body	Body Control Module																																																													
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2014	Spark	Body	Passenger Presence Module																																																													
M	2014	Spark	Body	Instrument Cluster																																																													
M	2014	Spark	Body	Radio																																																												
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																													
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																													
M	2014	Spark	Body	Keyless Entry Control Module																																																													
M	2014	Spark EV	Powertrain	Engine Control Module																																																													
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																													
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																													
M	2014	Spark EV	Powertrain	Drive Motor Control Module																																																													
M	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																													
M	2014	Spark EV	Chassis	Electronic Brake Control Module																																																													
M	2014	Spark EV	Chassis	Parking Brake Control Module																																																													
M	2014	Spark EV	Chassis	Power Steering Control Module																																																													
M	2014	Spark EV	Body	Body Control Module																																																													
M	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																													
M	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2014	Spark EV	Body	Passenger Presence Module																																																													
M	2014	Spark EV	Body	Instrument Cluster																																																													
M	2014	Spark EV	Body	Radio																																																												
M	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																													
M	2014	Spark EV	Body	HVAC Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
M	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																														
M	2014	Spark EV	Body	Coolant Heater Control Module																																																														
M	2014	Spark EV	Body	Keyless Entry Control Module																																																														
M	2014	Spark EV	Body	Battery Charger Control Module																																																														
M	2014	Spark EV	Body	DC Charging Control Module																																																														
M	2014	Spark EV	Body	Battery Energy Control Module																																																														
M	2015	Matiz	Powertrain	1.0L LA2 Engine Control Module																																																														
M	2015	Matiz	Chassis	Electronic Brake Control Module																																																														
M	2015	Matiz	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2015	Matiz	Body	Keyless Entry Control Module																																																														
M	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																														
M	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																														
M	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																														
M	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																														
M	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																														
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																														
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																														
M	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																														
M	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																														
M	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																														
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																														
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																														
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																														
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																														
M	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																														
M	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																														
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																														
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																														
M	2015	Spark	Powertrain	Fuel Injector Control Module																																																														
M	2015	Spark	Chassis	Electronic Brake Control Module																																																														
M	2015	Spark	Chassis	Electronic Brake Control Module																																																														
M	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																														
M	2015	Spark	Chassis	Power Steering Control Module																																																														
M	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																														
M	2015	Spark	Body	Body Control Module																																																														
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2015	Spark	Body	Passenger Presence Module																																																														
M	2015	Spark	Body	Instrument Cluster																																																														
M	2015	Spark	Body	Instrument Cluster																																																														
M	2015	Spark	Body	Tire Pressure Indicator Module																																																														
M	2015	Spark	Body	Radio																																																														
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																														
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																														
M	2015	Spark	Body	Keyless Entry Control Module																																																														
M	2015	Spark EV	Powertrain	Engine Control Module																																																														
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																														
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																														
M	2015	Spark EV	Powertrain	Drive Motor Control Module																																																														
M	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
M	2015	Spark EV	Chassis	Electronic Brake Control Module																																																														
M	2015	Spark EV	Chassis	Parking Brake Control Module																																																														
M	2015	Spark EV	Chassis	Power Steering Control Module																																																														
M	2015	Spark EV	Body	Body Control Module																																																														
M	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																														
M	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2015	Spark EV	Body	Passenger Presence Module																																																														
M	2015	Spark EV	Body	Instrument Cluster																																																														
M	2015	Spark EV	Body	Radio																																																														
M	2015	Spark EV	Body	HVAC Control Module																																																														
M	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																														
M	2015	Spark EV	Body	Coolant Heater Control Module																																																														
M	2015	Spark EV	Body	Keyless Entry Control Module																																																														
M	2015	Spark EV	Body	Battery Charger Control Module																																																														
M	2015	Spark EV	Body	DC Charging Control Module																																																														
M	2015	Spark EV	Body	Battery Energy Control Module																																																														
M	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																														
M	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																														
M	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																														
M	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																														
M	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																														
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																														
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																														
M	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																														
M	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																														
M	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																														
M	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																														
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																														
M	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																														
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																														
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																														
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																														
M	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																														
M	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																														
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																														
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																														
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																														
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																														
M	2016	Spark	Powertrain	Fuel Injector Control Module																																																														
M	2016	Spark	Chassis	Electronic Brake Control Module																																																														
M	2016	Spark	Chassis	Electronic Brake Control Module																																																														
M	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																														
M	2016	Spark	Chassis	Power Steering Control Module																																																														
M	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																														
M	2016	Spark	Body	Body Control Module																																																														
M	2016	Spark	Body	Body Control Module																																																														
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2016	Spark	Body	Instrument Cluster																																																														
M	2016	Spark	Body	Instrument Cluster																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
M	2016	Spark	Body	Radio																																																												
M	2016	Spark	Body	Telematics Communication Interface Control Module																																																												
M	2016	Spark	Body	Keyless Entry Control Module																																																												
M	2016	Spark EV	Powertrain	Engine Control Module																																																												
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																												
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																												
M	2016	Spark EV	Powertrain	Drive Motor Control Module																																																												
M	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																												
M	2016	Spark EV	Chassis	Electronic Brake Control Module																																																												
M	2016	Spark EV	Chassis	Parking Brake Control Module																																																												
M	2016	Spark EV	Chassis	Power Steering Control Module																																																												
M	2016	Spark EV	Body	Body Control Module																																																												
M	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																												
M	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2016	Spark EV	Body	Passenger Presence Module																																																												
M	2016	Spark EV	Body	Instrument Cluster																																																												
M	2016	Spark EV	Body	Radio																																																												
M	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																												
M	2016	Spark EV	Body	HVAC Control Module																																																												
M	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																												
M	2016	Spark EV	Body	Coolant Heater Control Module																																																												
M	2016	Spark EV	Body	Keyless Entry Control Module																																																												
M	2016	Spark EV	Body	Frontview Camera Module																																																												
M	2016	Spark EV	Body	Battery Charger Control Module																																																												
M	2016	Spark EV	Body	DC Charging Control Module																																																												
M	2016	Spark EV	Body	Battery Energy Control Module																																																												
N	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
N	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
N	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																												
N	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
N	2004	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
N	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																												
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																												
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																												
N	2004	Optra	Body	Remote Function Actuation																																																												
N	2004	Optra	Body	Supplemental Inflatable Restraint																																																												
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
N	2004	Classic	Chassis	Anti-lock Brake System																																																												
N	2004	Classic	Body	Body Control Module																																																												
N	2004	Classic	Body	Radio																																																												
N	2004	Classic	Body	Remote Function Actuation																																																												
N	2004	Classic	Body	Supplemental Inflatable Restraint																																																												
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																												
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Transmission Control Module																																																												
N	2004	Alero (Export)	Chassis	Anti-lock Brake System																																																												
N	2004	Alero (Export)	Body	Body Control Module																																																												
N	2004	Alero (Export)	Body	Instrument Panel Cluster																																																												
N	2004	Alero (Export)	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
N	2004	Alero (Export)	Body	Supplemental Inflatable Restraint																																																														
N	2004	Alero (Export)	Body	Vehicle Theft Deterrent																																																														
N	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																															
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																															
N	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																															
N	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																															
N	2005	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																															
N	2005	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
N	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																															
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																															
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																															
N	2005	Optra	Body	Remote Function Actuation																																																															
N	2005	Optra	Body	Supplemental Inflatable Restraint																																																															
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																															
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																															
N	2005	Classic	Chassis	Anti-lock Brake System																																																															
N	2005	Classic	Body	Body Control Module																																																															
N	2005	Classic	Body	Radio																																																															
N	2005	Classic	Body	Remote Function Actuation																																																															
N	2005	Classic	Body	Supplemental Inflatable Restraint																																																															
N	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																															
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																															
N	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																															
N	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																															
N	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																															
N	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																															
N	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
N	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																															
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																															
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																															
N	2006	ALL	Body	Remote Function Actuation																																																															
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																															
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																															
N	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																															
N	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																															
N	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																															
N	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																															
N	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
N	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																															
N	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																															
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																															
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																															
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																															
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																															
N	2007	ALL	Chassis	Tire Pressure Monitor																																																															
N	2007	ALL	Body	Remote Function Actuation																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
N	2007	ALL	Body	Supplemental Inflatable Restraint																																																														
N	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
N	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																															
N	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																															
N	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																															
N	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																															
N	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																															
N	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																																																															
N	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																															
N	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																															
N	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
N	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																															
N	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																															
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																															
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																															
N	2008	ALL	Chassis	Tire Pressure Monitor																																																															
N	2008	ALL	Body	Remote Function Actuation																																																															
N	2008	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
N	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																															
N	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																															
N	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																															
N	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																															
N	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																															
N	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																															
N	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																															
N	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
N	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																															
N	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																															
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																															
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																															
N	2009	ALL	Chassis	Tire Pressure Monitor																																																															
N	2009	ALL	Body	Remote Function Actuation																																																															
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2010	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
N	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																															
N	2010	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																															
N	2010	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																															
N	2010	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																															
N	2010	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
N	2010	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																															
N	2010	ALL	Powertrain	Transmission Control Module 5 Speed																																																															
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																															
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																															
N	2010	ALL	Chassis	Tire Pressure Monitor																																																															
N	2010	ALL	Body	Remote Function Actuation																																																															
N	2010	ALL	Body	Remote Function Actuation																																																															
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
N	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																														
N	2011	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																														
N	2011	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																														
N	2011	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																														
N	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
N	2011	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																														
N	2011	ALL	Powertrain	Transmission Control Module 5 Speed																																																														
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																														
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																														
N	2011	ALL	Chassis	Tire Pressure Monitor																																																														
N	2011	ALL	Body	Remote Function Actuation																																																														
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																														
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																														
N	2012	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																														
N	2012	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																														
N	2012	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																														
N	2012	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																														
N	2012	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
N	2012	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																														
N	2012	ALL	Powertrain	Transmission Control Module 5 Speed																																																														
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																														
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																														
N	2012	ALL	Chassis	Tire Pressure Monitor																																																														
N	2012	ALL	Body	Remote Function Actuation																																																														
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																														
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																														
N	2013	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																														
N	2013	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																														
N	2013	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																														
N	2013	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																														
N	2013	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
N	2013	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																														
N	2013	ALL	Powertrain	Transmission Control Module 5 Speed																																																														
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																														
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																														
N	2013	ALL	Chassis	Tire Pressure Monitor																																																														
N	2013	ALL	Body	Remote Function Actuation																																																														
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																														
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																														
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																														
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																														
N	2014	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																														
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																														
N	2014	Caprice	Powertrain	(2) 6.0L L77 Chassis Control Module																																																														
N	2014	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																														
N	2014	Caprice	Chassis	Electronic Brake Control Module																																																														
N	2014	Caprice	Chassis	Parking Brake Control Module																																																														
N	2014	Caprice	Chassis	Power Steering Control Module																																																														
N	2014	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																														
N	2014	Caprice	Body	Body Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
N	2014	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
N	2014	Caprice	Body	Passenger Presence Module																																																														
N	2014	Caprice	Body	Instrument Cluster																																																														
N	2014	Caprice	Body	Radio Controls																																																														
N	2014	Caprice	Body	HVAC Controls																																																														
N	2014	Caprice	Body	Headlamp Control Module																																																														
N	2014	Caprice	Body	Trailer Interface Control Module																																																														
N	2014	Caprice	Body	Radio																																																														
N	2014	Caprice	Body	HVAC Control Module																																																														
N	2014	Caprice	Body	Parking Assist Control Module																																																														
N	2014	Caprice	Body	Frontview Camera Module																																																														
N	2014	Caprice	Body	Steering Column Lock Control Module																																																														
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																														
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																														
N	2015	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																														
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																														
N	2015	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																														
N	2015	Caprice	Powertrain	Fuel Injector Control Module																																																														
N	2015	Caprice	Chassis	Electronic Brake Control Module																																																														
N	2015	Caprice	Chassis	Parking Brake Control Module																																																														
N	2015	Caprice	Chassis	Power Steering Control Module																																																														
N	2015	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																														
N	2015	Caprice	Chassis	Suspension Control Module																																																														
N	2015	Caprice	Body	Body Control Module																																																														
N	2015	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
N	2015	Caprice	Body	Passenger Presence Module																																																														
N	2015	Caprice	Body	Instrument Cluster																																																														
N	2015	Caprice	Body	Head-Up Display Module																																																														
N	2015	Caprice	Body	Radio Controls																																																														
N	2015	Caprice	Body	HVAC Controls																																																														
N	2015	Caprice	Body	Headlamp Control Module																																																														
N	2015	Caprice	Body	Trailer Interface Control Module																																																														
N	2015	Caprice	Body	Radio																																																														
N	2015	Caprice	Body	Telematics Communication Interface Control Module																																																														
N	2015	Caprice	Body	HVAC Control Module																																																														
N	2015	Caprice	Body	Right Side Object Detection Control Module																																																														
N	2015	Caprice	Body	Left Side Object Detection Control Module																																																														
N	2015	Caprice	Body	Parking Assist Control Module																																																														
N	2015	Caprice	Body	Frontview Camera Module																																																														
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																														
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																														
N	2016	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																														
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																														
N	2016	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																														
N	2016	Caprice	Powertrain	Fuel Injector Control Module																																																														
N	2016	Caprice	Chassis	Electronic Brake Control Module																																																														
N	2016	Caprice	Chassis	Parking Brake Control Module																																																														
N	2016	Caprice	Chassis	Power Steering Control Module																																																														
N	2016	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
N	2016	Caprice	Chassis	Suspension Control Module																																																													
N	2016	Caprice	Body	Body Control Module																																																													
N	2016	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
N	2016	Caprice	Body	Passenger Presence Module																																																													
N	2016	Caprice	Body	Instrument Cluster																																																													
N	2016	Caprice	Body	Head-Up Display Module																																																													
N	2016	Caprice	Body	Radio Controls																																																												
N	2016	Caprice	Body	HVAC Controls																																																												
N	2016	Caprice	Body	Trailer Interface Control Module																																																												
N	2016	Caprice	Body	Radio																																																												
N	2016	Caprice	Body	Telematics Communication Interface Control Module																																																												
N	2016	Caprice	Body	HVAC Control Module																																																												
N	2016	Caprice	Body	Seat Memory Control Module - Driver																																																												
N	2016	Caprice	Body	Right Side Object Detection Control Module																																																												
N	2016	Caprice	Body	Left Side Object Detection Control Module																																																												
N	2016	Caprice	Body	Parking Assist Control Module																																																												
N	2016	Caprice	Body	Frontview Camera Module																																																												
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																												
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																												
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																												
P	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																												
P	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																												
P	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																												
P	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																												
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																												
P	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																												
P	2010	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2010	Cruze	Body	Body Control Module																																																												
P	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2010	Cruze	Body	Passenger Presence Module																																																												
P	2010	Cruze	Body	Instrument Cluster																																																												
P	2010	Cruze	Body	Trailer Interface Control Module																																																												
P	2010	Cruze	Body	Radio																																																												
P	2010	Cruze	Body	Multimedia Player Interface Module																																																												
P	2010	Cruze	Body	Mobile Telephone Control Module																																																												
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
P	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																												
P	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																												
P	2010	Cruze	Body	Keyless Entry Control Module																																																												
P	2010	Cruze	Body	Parking Assist Control Module																																																												
P	2010	Cruze	Body	Steering Column Lock Control Module																																																												
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																											
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																											
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																											
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																											
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																											
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																											
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2011	Cruze	Chassis	Electronic Brake Control Module																																																											
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2011	Cruze	Body	Body Control Module																																						V																					
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2011	Cruze	Body	Passenger Presence Module																																																											
P	2011	Cruze	Body	Instrument Cluster																																																											
P	2011	Cruze	Body	Trailer Interface Control Module																																																											
P	2011	Cruze	Body	Radio																																																										
P	2011	Cruze	Body	Multimedia Player Interface Module																																																											
P	2011	Cruze	Body	Mobile Telephone Control Module																																																											
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2011	Cruze	Body	Keyless Entry Control Module																																																											
P	2011	Cruze	Body	Parking Assist Control Module																																																											
P	2011	Cruze	Body	Steering Column Lock Control Module																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																											
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
P	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																														
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																														
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																														
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																														
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																														
P	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																														
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																														
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																														
P	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																														
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																														
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																														
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																														
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																														
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																														
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																														
P	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																														
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																														
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																														
P	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																														
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																														
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																														
P	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																														
P	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																														
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																														
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																														
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																														
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																														
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																														
P	2012	Cruze	Chassis	Electronic Brake Control Module																																																														
P	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																														
P	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																														
P	2012	Cruze	Body	Body Control Module Hatchback																																					V																							
P	2012	Cruze	Body	Body Control Module Sedan																																					V																							
P	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
P	2012	Cruze	Body	Passenger Presence Module																																																														
P	2012	Cruze	Body	Instrument Cluster																																																														
P	2012	Cruze	Body	Trailer Interface Control Module																																																														
P	2012	Cruze	Body	Radio																																																														
P	2012	Cruze	Body	Multimedia Player Interface Module																																																														
P	2012	Cruze	Body	Mobile Telephone Control Module																																																														
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																														
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																														
P	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																													
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																													
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																													
P	2012	Cruze	Body	Keyless Entry Control Module																																																														
P	2012	Cruze	Body	Parking Assist Control Module																																																														
P	2012	Cruze	Body	Steering Column Lock Control Module																																																														
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																														
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																														
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																													
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																													
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																													
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																													
P	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																													
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																													
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																													
P	2013	Cruze	Chassis	Electronic Brake Control Module																																																													
P	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																													
P	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
P	2013	Cruze	Body	Body Control Module Hatchback																																						V																						
P	2013	Cruze	Body	Body Control Module Sedan																																						V																						
P	2013	Cruze	Body	Body Control Module Station Wagon																																						V																						
P	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2013	Cruze	Body	Passenger Presence Module																																																													
P	2013	Cruze	Body	Instrument Cluster																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
P	2013	Cruze	Body	Trailer Interface Control Module																																																													
P	2013	Cruze	Body	Radio																																																													
P	2013	Cruze	Body	Digital Radio Receiver Control Module																																																													
P	2013	Cruze	Body	Multimedia Player Interface Module																																																													
P	2013	Cruze	Body	Mobile Telephone Control Module																																																													
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																													
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																													
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																													
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																													
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																													
P	2013	Cruze	Body	Front Seat Heating Control Module																																																													
P	2013	Cruze	Body	Keyless Entry Control Module																																																													
P	2013	Cruze	Body	Right Side Object Detection Control Module																																																													
P	2013	Cruze	Body	Left Side Object Detection Control Module																																																													
P	2013	Cruze	Body	Parking Assist Control Module																																																													
P	2013	Cruze	Body	Steering Column Lock Control Module																																																													
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																													
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																													
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																													
P	2014	Cruze	Powertrain	Fuel Injector Control Module																																																														
P	2014	Cruze	Chassis	Electronic Brake Control Module																																																													
P	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																													
P	2014	Cruze	Chassis	Power Steering Control Module																																																													
P	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
P	2014	Cruze	Body	Body Control Module Hatchback																																						V																						
P	2014	Cruze	Body	Body Control Module Sedan																																						V																						
P	2014	Cruze	Body	Body Control Module Station Wagon																																						V																						
P	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
P	2014	Cruze	Body	Passenger Presence Module																																																													
P	2014	Cruze	Body	Instrument Cluster																																																													
P	2014	Cruze	Body	Trailer Interface Control Module																																																													
P	2014	Cruze	Body	Radio																																																													
P	2014	Cruze	Body	Digital Radio Receiver Control Module																																																													
P	2014	Cruze	Body	Multimedia Player Interface Module																																																													
P	2014	Cruze	Body	Mobile Telephone Control Module																																																													
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																													
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																													
P	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																													
P	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																													
P	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																													
P	2014	Cruze	Body	Front Seat Heating Control Module																																																													
P	2014	Cruze	Body	Keyless Entry Control Module																																																													
P	2014	Cruze	Body	Right Side Object Detection Control Module																																																													
P	2014	Cruze	Body	Left Side Object Detection Control Module																																																													
P	2014	Cruze	Body	Parking Assist Control Module																																																													
P	2014	Cruze	Body	Steering Column Lock Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																											
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																											
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																											
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																											
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																											
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																											
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																											
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																											
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																											
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																											
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																											
P	2015	Cruze	Powertrain	Fuel Injector Control Module																																																												
P	2015	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2015	Cruze	Chassis	Power Steering Control Module																																																												
P	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2015	Cruze	Body	Body Control Module Hatchback																																						V																					
P	2015	Cruze	Body	Body Control Module Sedan																																						V																					
P	2015	Cruze	Body	Body Control Module Station Wagon																																						V																					
P	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2015	Cruze	Body	Passenger Presence Module																																																												
P	2015	Cruze	Body	Instrument Cluster																																																												
P	2015	Cruze	Body	Trailer Interface Control Module																																																												
P	2015	Cruze	Body	Radio																																																											
P	2015	Cruze	Body	Digital Radio Receiver Control Module																																																												
P	2015	Cruze	Body	Multimedia Player Interface Module																																																												
P	2015	Cruze	Body	Mobile Telephone Control Module																																																												
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
P	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																		V								
P	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																												
P	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																		V								
P	2015	Cruze	Body	Front Seat Heating Control Module																																																												
P	2015	Cruze	Body	Keyless Entry Control Module																																																												
P	2015	Cruze	Body	Right Side Object Detection Control Module																																																												
P	2015	Cruze	Body	Left Side Object Detection Control Module																																																												
P	2015	Cruze	Body	Parking Assist Control Module																																																												
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2016	Cruze	Powertrain	Fuel Injector Control Module																																																												
P	2016	Cruze	Powertrain	Chassis Control Module																																																												
P	2016	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2016	Cruze	Chassis	Power Steering Control Module																																																												
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2016	Cruze	Body	Body Control Module Hatchback																																																												
P	2016	Cruze	Body	Body Control Module Sedan																																																												
P	2016	Cruze	Body	Body Control Module Station Wagon																																																												
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2016	Cruze	Body	Passenger Presence Module																																																												
P	2016	Cruze	Body	Instrument Cluster																																																												
P	2016	Cruze	Body	Trailer Interface Control Module																																																												
P	2016	Cruze	Body	Radio Other																																																											
P	2016	Cruze	Body	Radio (UF7)																																																											
P	2016	Cruze	Body	Multimedia Player Interface Module																																																											
P	2016	Cruze	Body	Mobile Telephone Control Module																																																											
P	2016	Cruze	Body	Telematics Communication Interface Control Module																																																											
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																											
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																											
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																											
P	2016	Cruze	Body	Front Seat Heating Control Module																																																											
P	2016	Cruze	Body	Keyless Entry Control Module																																																											
P	2016	Cruze	Body	Right Side Object Detection Control Module																																																											
P	2016	Cruze	Body	Left Side Object Detection Control Module																																																											
P	2016	Cruze	Body	Parking Assist Control Module																																																											
P	2016	Cruze	Body	Steering Column Lock Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2011	Volt	Powertrain	Engine Control Module																																																													
R	2011	Volt	Powertrain	Trasmission Control Module																																																													
R	2011	Volt	Powertrain	Fuel Pump Control Module																																																													
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module																																																												
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																												
R	2011	Volt	Powertrain	Drive Motor Control Module 1																																																												
R	2011	Volt	Powertrain	Drive Motor Control Module 2																																																												
R	2011	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2011	Volt	Chassis	Electronic Brake Control Module																																																												
R	2011	Volt	Chassis	Parking Brake Control Module																																																												
R	2011	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
R	2011	Volt	Chassis	Power Steering Control Module																																																												
R	2011	Volt	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2011	Volt	Body	Body Control Module																																																												
R	2011	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2011	Volt	Body	Passenger Presence Module																																																												
R	2011	Volt	Body	Instrument Cluster																																																												
R	2011	Volt	Body	Radio																																																												
R	2011	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2011	Volt	Body	Mobile Telephone Control Module																																																												
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2011	Volt	Body	Remote Heater and Air Conditioning Control Module																																																												
R	2011	Volt	Body	Electric A/C Compressor Control Module																																																												
R	2011	Volt	Body	Coolant Heater Control Module																																																												
R	2011	Volt	Body	Keyless Entry Control Module																																																												
R	2011	Volt	Body	Parking Assist Control Module																																																												
R	2011	Volt	Body	Steering Column Lock Control Module																																																												
R	2011	Volt	Body	Battery Charger Control Module																																																												
R	2011	Volt	Body	Battery Energy Control Module																																																												
R	2012	Volt	Powertrain	Engine Control Module																																																												
R	2012	Volt	Powertrain	Trasmission Control Module																																																												
R	2012	Volt	Powertrain	Fuel Pump Control Module																																																												
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module																																																												
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																												
R	2012	Volt	Powertrain	Drive Motor Control Module 1																																																												
R	2012	Volt	Powertrain	Drive Motor Control Module 2																																																												
R	2012	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2012	Volt	Chassis	Electronic Brake Control Module																																																												
R	2012	Volt	Chassis	Parking Brake Control Module																																																												
R	2012	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
R	2012	Volt	Chassis	Power Steering Control Module																																																												
R	2012	Volt	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2012	Volt	Body	Body Control Module																																																												
R	2012	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2012	Volt	Body	Passenger Presence Module																																																												
R	2012	Volt	Body	Instrument Cluster																																																												
R	2012	Volt	Body	Radio																																																												
R	2012	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2012	Volt	Body	Mobile Telephone Control Module																																																												
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 9																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2012	Volt	Body	Remote Heater and Air Conditioning Control Module																																																		V								
R	2012	Volt	Body	Electric A/C Compressor Control Module																																																											
R	2012	Volt	Body	Coolant Heater Control Module																																																											
R	2012	Volt	Body	Keyless Entry Control Module																																																											
R	2012	Volt	Body	Parking Assist Control Module																																																											
R	2012	Volt	Body	Steering Column Lock Control Module																																																											
R	2012	Volt	Body	Battery Charger Control Module																																																											
R	2012	Volt	Body	Battery Energy Control Module																																																											
R	2013	Volt	Powertrain	Engine Control Module																																																											
R	2013	Volt	Powertrain	Trasmission Control Module																																																											
R	2013	Volt	Powertrain	Fuel Pump Control Module																																																											
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module																																																											
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2013	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2013	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2013	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2013	Volt	Chassis	Electronic Brake Control Module																																																											
R	2013	Volt	Chassis	Parking Brake Control Module																																																											
R	2013	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
R	2013	Volt	Chassis	Power Steering Control Module																																																											
R	2013	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2013	Volt	Body	Body Control Module																																																											
R	2013	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2013	Volt	Body	Passenger Presence Module																																																											
R	2013	Volt	Body	Instrument Cluster																																																											
R	2013	Volt	Body	Radio																																																											
R	2013	Volt	Body	Digital Radio Receiver Control Module																																																											
R	2013	Volt	Body	Multimedia Player Interface Module																																																											
R	2013	Volt	Body	Mobile Telephone Control Module																																																											
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2013	Volt	Body	HVAC Control Module																																																											
R	2013	Volt	Body	Electric A/C Compressor Control Module																																																											
R	2013	Volt	Body	Coolant Heater Control Module																																																											
R	2013	Volt	Body	Front Seat Heating Control Module																																																											
R	2013	Volt	Body	Keyless Entry Control Module																																																											
R	2013	Volt	Body	Parking Assist Control Module																																																											
R	2013	Volt	Body	Frontview Camera Module																																																											
R	2013	Volt	Body	Steering Column Lock Control Module																																																											
R	2013	Volt	Body	Battery Charger Control Module																																																											
R	2013	Volt	Body	Battery Energy Control Module																																																											
R	2014	Volt	Powertrain	Engine Control Module																																																											
R	2014	Volt	Powertrain	Trasmission Control Module																																																											
R	2014	Volt	Powertrain	Chassis Control Module																																																											
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module																																																											
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2014	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2014	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2014	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2014	Volt	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2014	Volt	Chassis	Parking Brake Control Module																																																													
R	2014	Volt	Chassis	Power Steering Control Module																																																													
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2014	Volt	Body	Body Control Module																																																												
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Volt	Body	Passenger Presence Module																																																												
R	2014	Volt	Body	Instrument Cluster																																																												
R	2014	Volt	Body	Radio																																																												
R	2014	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Volt	Body	HVAC Control Module																																																					V							
R	2014	Volt	Body	Electric A/C Compressor Control Module																																																												
R	2014	Volt	Body	Coolant Heater Control Module																																																												
R	2014	Volt	Body	Front Seat Heating Control Module																																																												
R	2014	Volt	Body	Keyless Entry Control Module																																																												
R	2014	Volt	Body	Parking Assist Control Module																																																												
R	2014	Volt	Body	Frontview Camera Module																																																												
R	2014	Volt	Body	Steering Column Lock Control Module																																																												
R	2014	Volt	Body	Battery Charger Control Module																																																												
R	2014	Volt	Body	Battery Energy Control Module																																																												
R	2015	Volt	Powertrain	Engine Control Module																																																												
R	2015	Volt	Powertrain	Trasmission Control Module																																																												
R	2015	Volt	Powertrain	Chassis Control Module																																																												
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module																																																												
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																												
R	2015	Volt	Powertrain	Drive Motor Control Module 1																																																												
R	2015	Volt	Powertrain	Drive Motor Control Module 2																																																												
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2015	Volt	Chassis	Electronic Brake Control Module																																																												
R	2015	Volt	Chassis	Parking Brake Control Module																																																												
R	2015	Volt	Chassis	Power Steering Control Module																																																												
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2015	Volt	Body	Body Control Module																																																												
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Volt	Body	Passenger Presence Module																																																												
R	2015	Volt	Body	Instrument Cluster																																																												
R	2015	Volt	Body	Radio																																																												
R	2015	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2015	Volt	Body	Telematics Communication Interface Control Module																																																												
R	2015	Volt	Body	HVAC Control Module																																																				V							
R	2015	Volt	Body	Electric A/C Compressor Control Module																																																												
R	2015	Volt	Body	Coolant Heater Control Module																																																												
R	2015	Volt	Body	Front Seat Heating Control Module																																																												
R	2015	Volt	Body	Keyless Entry Control Module																																																												
R	2015	Volt	Body	Parking Assist Control Module																																																												
R	2015	Volt	Body	Frontview Camera Module																																																												
R	2015	Volt	Body	Steering Column Lock Control Module																																																												
R	2015	Volt	Body	Battery Charger Control Module																																																												
R	2015	Volt	Body	Battery Energy Control Module																																																												
R	2016	Volt	Powertrain	Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module																																																													
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																													
R	2016	Volt	Powertrain	Drive Motor Control Module 1																																																													
R	2016	Volt	Powertrain	Drive Motor Control Module 2																																																													
R	2016	Volt	Chassis	Electronic Brake Control Module																																																													
R	2016	Volt	Chassis	Brake Booster Control Module																																																													
R	2016	Volt	Chassis	Power Steering Control Module																																																													
R	2016	Volt	Body	Body Control Module																																																													
R	2016	Volt	Body	Pedestrian Alert Sound Control Module																																																													
R	2016	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
R	2016	Volt	Body	Passenger Presence Module																																																													
R	2016	Volt	Body	Instrument Cluster																																																													
R	2016	Volt	Body	Radio Controls																																																												
R	2016	Volt	Body	HVAC Controls																																																												
R	2016	Volt	Body	Radio																																																												
R	2016	Volt	Body	Amplifier																																																												
R	2016	Volt	Body	Human Machine Interface Control Module																																																												
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 9.7																																																												
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2016	Volt	Body	HVAC Control Module																																																													
R	2016	Volt	Body	Electric A/C Compressor Control Module																																																												
R	2016	Volt	Body	Keyless Entry Control Module																																																												
R	2016	Volt	Body	Right Side Object Detection Control Module																																																												
R	2016	Volt	Body	Left Side Object Detection Control Module																																																												
R	2016	Volt	Body	Parking Assist Control Module																																																												
R	2016	Volt	Body	Frontview Camera Module																																																												
R	2016	Volt	Body	Steering Column Lock Control Module																																																												
R	2016	Volt	Body	Battery Energy Control Module																																																												
R	2016	Volt	Body	Long Range Radar Sensor Module																																																												
S	2004	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																												
S	2004	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																												
S	2004	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
S	2004	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																												
S	2004	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
S	2004	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
S	2004	Aveo	Powertrain	Transmission Control Module																																																												
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2004	Aveo	Body	Supplemental Inflatable Restraint																																																												
S	2004	Aveo	Body	Remote Function Actuation																																																												
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																												
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																												
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																												
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																												
S	2005	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																												
S	2005	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
S	2005	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																												
S	2005	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
S	2005	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
S	2005	Aveo	Powertrain	Transmission Control Module																																																												
S	2005	Aveo	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2005	Aveo	Body	Supplemental Inflatable Restraint																																																														
S	2005	Aveo	Body	Remote Function Actuation																																																														
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																														
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																														
S	2006	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																														
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																														
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																														
S	2006	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																														
S	2006	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																														
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																														
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																														
S	2006	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
S	2006	Aveo	Chassis	Electronic Brake Control Module																																																															
S	2006	Aveo	Body	Supplemental Inflatable Restraint																																																															
S	2006	Aveo	Body	Remote Function Actuation																																																															
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																															
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																															
S	2007	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																															
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																															
S	2007	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																															
S	2007	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																															
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																															
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																															
S	2007	Aveo	Powertrain	Transmission Control Module 4 Speed																																																															
S	2007	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
S	2007	Aveo	Chassis	Electronic Brake Control Module																																																															
S	2007	Aveo	Body	Supplemental Inflatable Restraint																																																															
S	2007	Aveo	Body	Remote Function Actuation																																																															
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																															
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																															
S	2008	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																															
S	2008	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																															
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																															
S	2008	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																															
S	2008	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																															
S	2008	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																															
S	2008	Aveo	Powertrain	Transmission Control Module																																																															
S	2008	Aveo	Powertrain	Transmission Control Module																																																															
S	2008	Aveo	Chassis	Electronic Brake Control Module																																																															
S	2008	Aveo	Chassis	Tire Pressure Monitor																																																															
S	2008	Aveo	Body	Supplemental Inflatable Restraint																																																															
S	2008	Aveo	Body	Remote Function Actuation																																																															
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																															
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																															
S	2009	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																															
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																															
S	2009	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																															
S	2009	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2009	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module										V																																																				
S	2009	Aveo	Powertrain	Transmission Control Module																																																														
S	2009	Aveo	Powertrain	Transmission Control Module																																																													
S	2009	Aveo	Powertrain	Other Auto Transmission System																																																													
S	2009	Aveo	Chassis	Electronic Brake Control Module																																																													
S	2009	Aveo	Chassis	Tire Pressure Monitor																																																													
S	2009	Aveo	Body	Supplemental Inflatable Restraint																																																													
S	2009	Aveo	Body	Remote Function Actuation																																																													
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																													
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																													
S	2010	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																													
S	2010	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
S	2010	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																													
S	2010	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																													
S	2010	Aveo	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																													
S	2010	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module										V																																																			
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																													
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																													
S	2010	Aveo	Chassis	Electronic Brake Control Module																																																													
S	2010	Aveo	Chassis	Tire Pressure Monitor																																																													
S	2010	Aveo	Body	Supplemental Inflatable Restraint																																																													
S	2010	Aveo	Body	Remote Function Actuation																																																													
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																													
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																													
S	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																													
S	2010	Sail	Powertrain	Transmission Control Module																																																													
S	2010	Sail	Chassis	Electronic Brake Control Module																																																													
S	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																													
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																													
S	2011	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																													
S	2011	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
S	2011	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																													
S	2011	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																													
S	2011	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module										V																																																			
S	2011	Aveo	Powertrain	(G)1.6L L4 LXV Engine Control Module										V																																																			
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																													
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																													
S	2011	Aveo	Chassis	Electronic Brake Control Module																																																													
S	2011	Aveo	Chassis	Tire Pressure Monitor																																																													
S	2011	Aveo	Body	Supplemental Inflatable Restraint																																																													
S	2011	Aveo	Body	Remote Function Actuation																																																													
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																													
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																													
S	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																													
S	2011	Sail	Powertrain	Transmission Control Module																																																													
S	2011	Sail	Chassis	Electronic Brake Control Module																																																													
S	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																													
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																													
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																													
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																														
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																														
S	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																														
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
S	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																														
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																														
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																														
S	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																														
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																														
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																														
S	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																														
S	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																														
S	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																														
S	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																														
S	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																														
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																														
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																														
S	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																														
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																														
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																														
S	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																														
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																														
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																														
S	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																														
S	2012	Aveo	Powertrain	Fuel Pump Control Module																																																														
S	2012	Aveo	Powertrain	Fuel Injector Control Module																																																														
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																														
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																														
S	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2012	Aveo	Chassis	Electric Power Steering Control Module																																																														
S	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2012	Aveo	Chassis	Tire Pressure Monitor																																																														
S	2012	Aveo	Body	Body Control Module Hatchback																																																														
S	2012	Aveo	Body	Body Control Module Sedan																																																														
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2012	Aveo	Body	Passenger Presence Module																																																														
S	2012	Aveo	Body	Instrument Cluster																																																														
S	2012	Aveo	Body	Radio																																																														
S	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																														
S	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																														
S	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
S	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																														
S	2012	Aveo	Body	Front Seat Heating Control Module																																																														
S	2012	Aveo	Body	Remote Function Actuation																																																														
S	2012	Aveo	Body	Parking Assist Control Module																																																														
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																											
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																												
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																												
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																												
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																												
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																												
S	2012	Sail	Powertrain	Transmission Control Module																																																												
S	2012	Sail	Chassis	Electronic Brake Control Module																																																												
S	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
S	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
S	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																												
S	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
S	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																												
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
S	2013	Aveo	Powertrain	Fuel Injector Control Module																																																												
S	2013	Aveo	Powertrain	Fuel Pump Control Module																																																												
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2013	Aveo	Chassis	Electric Power Steering Control Module																																																												
S	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2013	Aveo	Body	Body Control Module Hatchback																																																												
S	2013	Aveo	Body	Body Control Module Sedan																																																												
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2013	Aveo	Body	Passenger Presence Module																																																												
S	2013	Aveo	Body	Instrument Cluster																																																												
S	2013	Aveo	Body	Radio																																																											
S	2013	Aveo	Body	Telematics Communication Interface Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																														
S	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
S	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																														
S	2013	Aveo	Body	Front Seat Heating Control Module																																																														
S	2013	Aveo	Body	Remote Function Actuation																																																														
S	2013	Aveo	Body	Parking Assist Control Module																																																														
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																														
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																														
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																														
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																														
S	2013	Sail	Powertrain	Transmission Control Module																																																														
S	2013	Sail	Chassis	Electronic Brake Control Module																																																														
S	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																															
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																														
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																														
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																														
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																														
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																														
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																														
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																														
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																														
S	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																														
S	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																														
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																														
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																														
S	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																														
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																														
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																														
S	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																														
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																														
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																														
S	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																														
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
S	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																														
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																														
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																														
S	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														
S	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																														
S	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																														
S	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																														
S	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																														
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																														
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																														
S	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																														
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																														
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																														
S	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
S	2014	Aveo	Powertrain	Chassis Control Module																																																												
S	2014	Aveo	Powertrain	Fuel Injector Control Module																																																												
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2014	Aveo	Chassis	Power Steering Control Module																																																												
S	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2014	Aveo	Body	Body Control Module Hatchback																																																												
S	2014	Aveo	Body	Body Control Module Sedan																																																												
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2014	Aveo	Body	Instrument Cluster																																																												
S	2014	Aveo	Body	Radio																																																												
S	2014	Aveo	Body	Telematics Communication Interface Control Module																																																												
S	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
S	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
S	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
S	2014	Aveo	Body	Front Seat Heating Control Module																																																												
S	2014	Aveo	Body	Keyless Entry Control Module																																																												
S	2014	Aveo	Body	Parking Assist Control Module																																																												
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																												
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																												
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																												
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																												
S	2014	Sail	Powertrain	Transmission Control Module																																																												
S	2014	Sail	Chassis	Electronic Brake Control Module																																																												
S	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																												
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
S	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																												
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																												
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																														
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
S	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																														
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																														
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																														
S	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														
S	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																														
S	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																														
S	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																														
S	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																														
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																														
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																														
S	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																														
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																														
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																														
S	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																														
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																														
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																														
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																														
S	2015	Aveo	Powertrain	Chassis Control Module																																																															
S	2015	Aveo	Powertrain	Fuel Injector Control Module																																																															
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																															
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																															
S	2015	Aveo	Chassis	Power Steering Control Module																																																															
S	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																															
S	2015	Aveo	Body	Body Control Module Hatchback																																																															
S	2015	Aveo	Body	Body Control Module Sedan																																																															
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2015	Aveo	Body	Instrument Cluster																																																															
S	2015	Aveo	Body	Radio																																																															
S	2015	Aveo	Body	Telematics Communication Interface Control Module																																																															
S	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																														
S	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
S	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																														
S	2015	Aveo	Body	Front Seat Heating Control Module																																																														
S	2015	Aveo	Body	Keyless Entry Control Module																																																														
S	2015	Aveo	Body	Parking Assist Control Module																																																														
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																														
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																														
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																														
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																														
S	2015	Sail	Powertrain	Transmission Control Module																																																															
S	2015	Sail	Chassis	Electronic Brake Control Module																																																														
S	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																														
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																														
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																													
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																													
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																													
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																													
S	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																													
S	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																													
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																													
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																													
S	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																													
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
S	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																													
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
S	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
S	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																													
S	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																													
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																													
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																													
S	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																													
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																													
S	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																													
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																													
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																													
S	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																													
S	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																													
S	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
S	2016	Aveo	Powertrain	Chassis Control Module																																																													
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2016	Aveo	Chassis	Power Steering Control Module																																																												
S	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2016	Aveo	Body	Body Control Module Hatchback																																																												
S	2016	Aveo	Body	Body Control Module Sedan																																																												
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2016	Aveo	Body	Instrument Cluster																																																												
S	2016	Aveo	Body	Radio																																																											
S	2016	Aveo	Body	Telematics Communication Interface Control Module																																																												
S	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
S	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
S	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
S	2016	Aveo	Body	Front Seat Heating Control Module																																																												
S	2016	Aveo	Body	Parking Assist Control Module																																																												
S	2016	Aveo	Body	Keyless Entry Control Module																																																												
S	2016	Aveo	Body	Frontview Camera Module																																																												
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																												
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																												
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																												
S	2016	Sail	Powertrain	Transmission Control Module																																																												
S	2016	Sail	Chassis	Electronic Brake Control Module																																																												
S	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2004	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																												
T	2004	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
T	2004	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																												
T	2004	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
T	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
T	2004	ALL	Powertrain	Transmission Control Module																																																												
T	2004	ALL	Chassis	Electronic Brake Control Module																																																												
T	2004	ALL	Chassis	Electronic Brake Control Module																																																												
T	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2004	ALL	Body	Remote Function Actuation																																																												
T	2005	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																												
T	2005	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
T	2005	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																												
T	2005	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
T	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
T	2005	ALL	Powertrain	Transmission Control Module																																																												
T	2005	ALL	Chassis	Electronic Brake Control Module																																																												
T	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2005	ALL	Body	Remote Function Actuation																																																												
T	2006	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																												
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																												
T	2006	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																												
T	2006	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
T	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
T	2006	ALL	Chassis	Electronic Brake Control Module																																																												
T	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2006	ALL	Body	Remote Function Actuation																																																												
T	2007	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																												
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																												
T	2007	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																												
T	2007	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
T	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																												
T	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
T	2007	ALL	Chassis	Electronic Brake Control Module																																																												
T	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2007	ALL	Body	Remote Function Actuation																																																												
T	2008	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
T	2008	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																												
T	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2008	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																														
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																														
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																														
T	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																														
T	2008	ALL	Powertrain	Transmission Control Module																																																														
T	2008	ALL	Powertrain	Transmission Control Module																																																														
T	2008	ALL	Chassis	Electronic Brake Control Module																																																														
T	2008	ALL	Chassis	Tire Pressure Monitor																																																														
T	2008	ALL	Body	Supplemental Inflatable Restraint																																																														
T	2008	ALL	Body	Remote Function Actuation																																																														
T	2008	ALL	Body	Passenger Presence System																																																														
T	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																														
T	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																														
T	2009	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module										V																																																			
T	2009	ALL	Powertrain	Transmission Control Module																																																														
T	2009	ALL	Powertrain	Transmission Control Module																																																														
T	2009	ALL	Chassis	Electronic Brake Control Module																																																														
T	2009	ALL	Chassis	Tire Pressure Monitor																																																														
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																														
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																														
T	2009	ALL	Body	Instrument Panel Cluster																																																														
T	2009	ALL	Body	Passenger Presence System																																																														
T	2009	ALL	Body	Theft Deterrent Module																																																														
T	2009	ALL	Body	Radio																																																														
T	2009	ALL	Body	Remote Function Actuation																																																														
T	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																														
T	2010	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																														
T	2010	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module										V																																																			
T	2010	ALL	Powertrain	Transmission Control Module																																																														
T	2010	ALL	Powertrain	Transmission Control Module																																																														
T	2010	ALL	Chassis	Electronic Brake Control Module																																																														
T	2010	ALL	Chassis	Tire Pressure Monitor																																																														
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																														
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																														
T	2010	ALL	Body	Instrument Panel Cluster																																																														
T	2010	ALL	Body	Passenger Presence System																																																														
T	2010	ALL	Body	Theft Deterrent Module																																																														
T	2010	ALL	Body	Radio																																																														
T	2010	ALL	Body	Remote Function Actuation																																																														
T	2011	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																														
T	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																														
T	2011	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																														
T	2011	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																														
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																														
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module Argentia																																																														
T	2011	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module										V																																																			
T	2011	ALL	Powertrain	(G)1.6L L4 LXV Engine Control Module										V																																																			
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
T	2011	ALL	Chassis	Electronic Brake Control Module																																																														
T	2011	ALL	Chassis	Tire Pressure Monitor																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2011	ALL	Body	Instrument Panel Cluster																																																												
T	2011	ALL	Body	Passenger Presence System																																																												
T	2011	ALL	Body	Theft Deterrent Module																																																												
T	2011	ALL	Body	Radio																																																												
T	2011	ALL	Body	Remote Function Actuation																																																												
T	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																												
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																												
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																												
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																												
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
T	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
T	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																												
T	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
T	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																												
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																												
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
T	2012	Aveo	Powertrain	Fuel Injector Control Module																																																												
T	2012	Aveo	Powertrain	Fuel Pump Control Module																																																												
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2012	Aveo	Chassis	Electric Power Steering Control Module																																																												
T	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2012	Aveo	Chassis	Tire Pressure Monitor																																																												
T	2012	Aveo	Body	Body Control Module Hatchback																																																												
T	2012	Aveo	Body	Body Control Module Sedan																																																												
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2012	Aveo	Body	Passenger Presence Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2012	Aveo	Body	Instrument Cluster																																																														
T	2012	Aveo	Body	Radio																																																														
T	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																															
T	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																														
T	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
T	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																														
T	2012	Aveo	Body	Front Seat Heating Control Module																																																														
T	2012	Aveo	Body	Remote Function Actuation																																																														
T	2012	Aveo	Body	Parking Assist Control Module																																																														
T	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																														
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																														
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																														
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																														
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																														
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																														
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																														
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																														
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																														
T	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																														
T	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																														
T	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																														
T	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																														
T	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																														
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																														
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																														
T	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																														
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																														
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																														
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																														
T	2013	Aveo	Powertrain	Fuel Injector Control Module																																																														
T	2013	Aveo	Powertrain	Fuel Pump Control Module																																																														
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																														
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																														
T	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																														
T	2013	Aveo	Chassis	Electric Power Steering Control Module																																																														
T	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																														
T	2013	Aveo	Body	Body Control Module Hatchback																																																														
T	2013	Aveo	Body	Body Control Module Sedan																																																														
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
T	2013	Aveo	Body	Passenger Presence Module																																																														
T	2013	Aveo	Body	Instrument Cluster																																																														
T	2013	Aveo	Body	Radio																																																														
T	2013	Aveo	Body	Telematics Communication Interface Control Module																																																														
T	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																														
T	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
T	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2013	Aveo	Body	Front Seat Heating Control Module																																																														
T	2013	Aveo	Body	Remote Function Actuation																																																														
T	2013	Aveo	Body	Parking Assist Control Module																																																														
T	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																														
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																														
T	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																														
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																														
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																														
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																														
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																														
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														
T	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																														
T	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																														
T	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																														
T	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																														
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																														
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																														
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																														
T	2014	Aveo	Powertrain	Chassis Control Module																																																														
T	2014	Aveo	Powertrain	Fuel Injector Control Module																																																														
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																														
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																														
T	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																														
T	2014	Aveo	Chassis	Power Steering Control Module																																																														
T	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																														
T	2014	Aveo	Body	Body Control Module Hatchback																																																														
T	2014	Aveo	Body	Body Control Module Sedan																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2014	Aveo	Body	Instrument Cluster																																																													
T	2014	Aveo	Body	Radio																																																												
T	2014	Aveo	Body	Telematics Communication Interface Control Module																																																												
T	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
T	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
T	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
T	2014	Aveo	Body	Front Seat Heating Control Module																																																												
T	2014	Aveo	Body	Keyless Entry Control Module																																																												
T	2014	Aveo	Body	Parking Assist Control Module																																																												
T	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																												
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
T	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																												
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																												
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
T	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
T	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
T	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
T	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
T	2015	Aveo	Powertrain	Chassis Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2015	Aveo	Powertrain	Fuel Injector Control Module																																																														
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																														
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																													
T	2015	Aveo	Chassis	Power Steering Control Module																																																													
T	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2015	Aveo	Body	Body Control Module Hatchback																																																													
T	2015	Aveo	Body	Body Control Module Sedan																																																													
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2015	Aveo	Body	Instrument Cluster																																																													
T	2015	Aveo	Body	Radio																																																												
T	2015	Aveo	Body	Telematics Communication Interface Control Module																																																												
T	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
T	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
T	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
T	2015	Aveo	Body	Front Seat Heating Control Module																																																												
T	2015	Aveo	Body	Keyless Entry Control Module																																																												
T	2015	Aveo	Body	Parking Assist Control Module																																																												
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
T	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
T	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
T	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
T	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
T	2016	Aveo	Powertrain	Chassis Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																														
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																														
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																														
T	2016	Aveo	Chassis	Power Steering Control Module																																																														
T	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																														
T	2016	Aveo	Body	Body Control Module Hatchback																																																														
T	2016	Aveo	Body	Body Control Module Sedan																																																														
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
T	2016	Aveo	Body	Instrument Cluster																																																														
T	2016	Aveo	Body	Radio																																																														
T	2016	Aveo	Body	Telematics Communication Interface Control Module																																																														
T	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
T	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																														
T	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																														
T	2016	Aveo	Body	Front Seat Heating Control Module																																																														
T	2016	Aveo	Body	Parking Assist Control Module																																																														
T	2016	Aveo	Body	Keyless Entry Control Module																																																														
T	2016	Aveo	Body	Frontview Camera Module																																																														
U	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																														
U	2004	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																														
U	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																														
U	2004	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																														
U	2004	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																														
U	2004	ALL	Chassis	Electronic Brake Control Module																																																														
U	2004	ALL	Chassis	Electronic Brake Control Module																																																														
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
U	2004	ALL	Body	Remote Function Actuation																																																														
U	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																														
U	2005	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																														
U	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																														
U	2005	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																													
U	2005	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																														
U	2005	ALL	Chassis	Electronic Brake Control Module																																																														
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
U	2005	ALL	Body	Remote Function Actuation																																																														
U	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																														
U	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																														
U	2006	ALL	Powertrain	Transmission Control Module																																																														
U	2006	ALL	Chassis	Electronic Brake Control Module																																																														
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																														
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																														
U	2006	ALL	Body	Remote Function Actuation																																																														
U	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																														
U	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																														
U	2007	ALL	Powertrain	Transmission Control Module																																																														
U	2007	ALL	Chassis	Electronic Brake Control Module																																																														
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																														
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
U	2007	ALL	Body	Remote Function Actuation																																																														
U	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																															
U	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																															
U	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																															
U	2008	ALL	Powertrain	Transmission Control Module																																																															
U	2008	ALL	Chassis	Electronic Brake Control Module																																																															
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																															
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																															
U	2008	ALL	Body	Remote Function Actuation																																																															
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																															
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																															
U	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																															
U	2010	Sail	Powertrain	Transmission Control Module																																																															
U	2010	Sail	Chassis	Electronic Brake Control Module																																																															
U	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																															
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																															
U	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																															
U	2011	Sail	Powertrain	Transmission Control Module																																																															
U	2011	Sail	Chassis	Electronic Brake Control Module																																																															
U	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																															
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																															
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																															
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																															
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																															
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																															
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																															
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																															
U	2012	Sail	Powertrain	Transmission Control Module																																																															
U	2012	Sail	Chassis	Electronic Brake Control Module																																																															
U	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																															
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																															
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																															
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																															
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																															
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																															
U	2013	Sail	Powertrain	Transmission Control Module																																																															
U	2013	Sail	Chassis	Electronic Brake Control Module																																																															
U	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																															
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																															
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																															
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																															
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																															
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																															
U	2014	Sail	Powertrain	Transmission Control Module																																																															
U	2014	Sail	Chassis	Electronic Brake Control Module																																																															
U	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																													
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																													
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
U	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																													
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																													
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																													
U	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																													
U	2015	Sail	Powertrain	Transmission Control Module																																																													
U	2015	Sail	Chassis	Electronic Brake Control Module																																																													
U	2015	Sail	Chassis	Electronic Brake Control Module																																																													
U	2015	Sail	Chassis	Power Steering Control Module																																																													
U	2015	Sail	Body	Body Control Module																																																													
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2015	Sail	Body	Radio/HVAC Control																																																													
U	2015	Sail	Body	HVAC Control Module																																																													
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																													
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																													
U	2016	Sail	Powertrain	1.2L LMU Transmission Control Module																																																													
U	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																													
U	2016	Sail	Powertrain	1.3L LDV Transmission Control Module																																																													
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																													
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																													
U	2016	Sail	Powertrain	1.4L LCU Transmission Control Module																																																													
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																													
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																													
U	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																													
U	2016	Sail	Chassis	Electronic Brake Control Module																																																													
U	2016	Sail	Chassis	Electronic Brake Control Module																																																													
U	2016	Sail	Chassis	Power Steering Control Module																																																													
U	2016	Sail	Body	Body Control Module																																																													
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2016	Sail	Body	Radio/HVAC Control																																																													
U	2016	Sail	Body	Radio																																																													
U	2016	Sail	Body	HVAC Control Module																																																													
V	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																													
V	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																													
V	2004	ALL	Powertrain	Transmission Control Module 4 Speed																																																													
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																													
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																													
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																													
V	2004	ALL	Body	ISU																																																												
V	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																													
V	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																													
V	2005	ALL	Powertrain	Transmission Control Module 4 Speed																																																													
V	2005	ALL	Chassis	Electronic Brake Control Module																																																													
V	2005	ALL	Body	Supplemental Inflatable Restraint																																																													
V	2005	ALL	Body	ISU																																																												
V	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																													
V	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
V	2006	ALL	Powertrain	Transmission Control Module 4 Speed																																																														
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																														
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																														
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2006	ALL	Body	ISU																																																														
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																														
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector Control Module																																																														
V	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																														
V	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module										V																																																				
V	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																														
V	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																														
V	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																														
V	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																														
V	2007	ALL	Chassis	Electronic Brake Control Module																																																														
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2007	ALL	Body	ISU																																																														
V	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																														
V	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																														
V	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																														
V	2008	ALL	Chassis	Electronic Brake Control Module																																																														
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2008	ALL	Body	ISU																																																														
V	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																														
V	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																														
V	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																														
V	2009	ALL	Chassis	Electronic Brake Control Module																																																														
V	2009	ALL	Body	ISU																																																														
V	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																															
V	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																														
V	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																														
V	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																														
V	2010	ALL	Chassis	Electronic Brake Control Module																																																														
V	2010	ALL	Body	ISU																																																														
V	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																														
V	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																														
V	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																														
V	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																														
V	2011	ALL	Chassis	Electronic Brake Control Module																																																														
V	2011	ALL	Body	ISU																																																														
W	2004	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																														
W	2004	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																														
W	2004	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																														
W	2004	ALL	Powertrain	Transmission Control Module																																																														
W	2004	ALL	Body	Body Control Module																																																														
W	2004	ALL	Body	Digital Radio Receiver																																																														
W	2004	ALL	Body	Driver Information Center																																																														
W	2004	ALL	Body	Heating and Air Conditioning																																																														
W	2004	ALL	Body	Instrument Panel Cluster																																																														
W	2004	ALL	Body	Personalization																																																														
W	2004	ALL	Body	Radio																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
W	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																												
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																												
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																												
W	2005	ALL	Powertrain	Transmission Control Module																																																												
W	2005	ALL	Body	Body Control Module																																																												
W	2005	ALL	Body	Digital Radio Receiver																																																												
W	2005	ALL	Body	Driver Information Center																																																												
W	2005	ALL	Body	Heating and Air Conditioning																																																												
W	2005	ALL	Body	Instrument Panel Cluster																																																												
W	2005	ALL	Body	Personalization																																																												
W	2005	ALL	Body	Radio																																																												
W	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																												
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																												
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																												
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																												
W	2006	ALL	Powertrain	Transmission Control Module																																																												
W	2006	ALL	Chassis	Anti-lock Brake System																																																												
W	2006	ALL	Body	Digital Radio Receiver																																																												
W	2006	ALL	Body	Radio																																																												
W	2006	ALL	Body	Instrument Panel Cluster																																																												
W	2006	ALL	Body	Seat																																																												
W	2006	ALL	Body	Theft Deterrent Module																																																												
W	2006	ALL	Body	Body Control Module														V																																														
W	2006	ALL	Body	HVAC C67 Single																																																												
W	2006	ALL	Body	HVAC CJ3 Dual																																																												
W	2006	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2006	ALL	Body	Passenger Presence System																																																												
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																												
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																												
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																												
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module																																																												
W	2007	ALL	Powertrain	Transmission Control Module																																																												
W	2007	ALL	Chassis	Electronic Brake Control Module																																																												
W	2007	ALL	Body	Body Control Module																																																												
W	2007	ALL	Body	Digital Radio Receiver																																																												
W	2007	ALL	Body	Heated Seat Module																																																												
W	2007	ALL	Body	HVAC C67 Single																																																												
W	2007	ALL	Body	HVAC CJ3 Dual																																																												
W	2007	ALL	Body	Instrument Panel Cluster																																																												
W	2007	ALL	Body	Passenger Presence System																																																												
W	2007	ALL	Body	Radio																																																												
W	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2007	ALL	Body	Theft Deterrent Module																																																												
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																												
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																												
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module																																																												
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																												
W	2008	ALL	Powertrain	Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
W	2008	ALL	Chassis	Electronic Brake Control Module																																																														
W	2008	ALL	Body	Body Control Module																																																														
W	2008	ALL	Body	Digital Radio Receiver																																																														
W	2008	ALL	Body	Heated Seat Module																																																														
W	2008	ALL	Body	HVAC C67 Single																																																														
W	2008	ALL	Body	HVAC CJ3 Dual																																																														
W	2008	ALL	Body	Instrument Panel Cluster																																																														
W	2008	ALL	Body	Passenger Presence System																																																														
W	2008	ALL	Body	Radio																																																														
W	2008	ALL	Body	Remote Control Door Lock Receiver																																																														
W	2008	ALL	Body	Supplemental Inflatable Restraint																																																														
W	2008	ALL	Body	Theft Deterrent Module																																																														
W	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module										V																																																				
W	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module										V																																																				
W	2009	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module										V																																																				
W	2009	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																															
W	2009	ALL	Powertrain	Transmission Control Module																																																															
W	2009	ALL	Chassis	Electronic Brake Control Module																																																															
W	2009	ALL	Body	Body Control Module														V	V	V	V	V	V	V	V																																										
W	2009	ALL	Body	Digital Radio Receiver																																																															
W	2009	ALL	Body	Heated Seat Module																																																															
W	2009	ALL	Body	HVAC C67 Single																																																															
W	2009	ALL	Body	HVAC CJ3 Dual																																																															
W	2009	ALL	Body	Instrument Panel Cluster																																																															
W	2009	ALL	Body	Passenger Presence System																																																															
W	2009	ALL	Body	Radio																																																															
W	2009	ALL	Body	Remote Control Door Lock Receiver																																																															
W	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
W	2009	ALL	Body	Theft Deterrent Module																																																															
W	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module										V																																																				
W	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module										V																																																				
W	2010	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module										V																																																				
W	2010	ALL	Powertrain	Transmission Control Module																																																															
W	2010	ALL	Chassis	Electronic Brake Control Module																																																															
W	2010	ALL	Body	Body Control Module														V	V	V	V	V	V	V	V																																										
W	2010	ALL	Body	Digital Radio Receiver																																																															
W	2010	ALL	Body	Heated Seat Module																																																															
W	2010	ALL	Body	HVAC C67 Single																																																															
W	2010	ALL	Body	HVAC CJ3 Dual																																																															
W	2010	ALL	Body	Instrument Panel Cluster																																																															
W	2010	ALL	Body	Passenger Presence System																																																															
W	2010	ALL	Body	Radio																																																															
W	2010	ALL	Body	Remote Control Door Lock Receiver																																																															
W	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
W	2010	ALL	Body	Theft Deterrent Module																																																															
W	2011	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module										V																																																				
W	2011	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module										V																																																				
W	2011	ALL	Powertrain	Transmission Control Module																																																															
W	2011	ALL	Chassis	Electronic Brake Control Module																																																															
W	2011	ALL	Body	Body Control Module														V	V	V	V	V	V	V	V																																										
W	2011	ALL	Body	Digital Radio Receiver																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
W	2011	ALL	Body	Heated Seat Module																																																										
W	2011	ALL	Body	HVAC C67 Single																																																										
W	2011	ALL	Body	HVAC CJ3 Dual																																																										
W	2011	ALL	Body	Instrument Panel Cluster																																																										
W	2011	ALL	Body	Passenger Presence System																																																										
W	2011	ALL	Body	Radio																																																										
W	2011	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2011	ALL	Body	Theft Deterrent Module																																																										
W	2012	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module										V																																																
W	2012	ALL	Powertrain	Transmission Control Module																																																										
W	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
W	2012	ALL	Chassis	Electronic Brake Control Module																																																										
W	2012	ALL	Body	Body Control Module														V	V	V	V	V	V	V	V																																					
W	2012	ALL	Body	Digital Radio Receiver																																																										
W	2012	ALL	Body	Heated Seat Module																																																										
W	2012	ALL	Body	HVAC C67 Single																																																										
W	2012	ALL	Body	HVAC CJ3 Dual																																																										
W	2012	ALL	Body	Instrument Panel Cluster																																																										
W	2012	ALL	Body	Passenger Presence System																																																										
W	2012	ALL	Body	Radio																																																										
W	2012	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2012	ALL	Body	Supplemental Inflatable Restraint																																V	V	V	V																							
W	2012	ALL	Body	Theft Deterrent Module																																																										
W	2013	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module										V																																																
W	2013	ALL	Powertrain	Transmission Control Module																																																										
W	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
W	2013	ALL	Chassis	Electronic Brake Control Module																																																										
W	2013	ALL	Body	Body Control Module														V	V	V	V	V	V	V	V																																					
W	2013	ALL	Body	Digital Radio Receiver																																																										
W	2013	ALL	Body	Heated Seat Module																																																										
W	2013	ALL	Body	HVAC C67 Single																																																										
W	2013	ALL	Body	HVAC CJ3 Dual																																																										
W	2013	ALL	Body	Instrument Panel Cluster																																																										
W	2013	ALL	Body	Passenger Presence System																																																										
W	2013	ALL	Body	Radio																																																										
W	2013	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2013	ALL	Body	Supplemental Inflatable Restraint																																V	V	V	V																							
W	2013	ALL	Body	Theft Deterrent Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
W	2014	Impala	Chassis	Electronic Brake Control Module																																																										
W	2014	Impala	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
W	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2014	Impala	Body	Passenger Presence Module																																															V											
W	2014	Impala	Body	Instrument Cluster																																																										
W	2014	Impala	Body	Radio																																																										
W	2014	Impala	Body	Digital Radio Receiver Control Module																																																										
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																										
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
W	2014	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																	V	V						
W	2014	Impala	Body	HVAC Manual Control Single Zone (C67)																																																	V	V						
W	2014	Impala	Body	Front Seat Heating Control Module																																																								
W	2014	Impala	Body	Remote Control Door Lock Receiver																																																								
W	2014	Impala	Body	Theft Deterrent Module																																																								
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																								
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																								
W	2014	Lumina	Powertrain	(2) 6.0L L77 Transmission Control Module																																																								
W	2014	Lumina	Powertrain	Fuel Injector Control Module																																																								
W	2014	Lumina	Powertrain	Chassis Control Module																																																								
W	2014	Lumina	Chassis	Electronic Brake Control Module																																																								
W	2014	Lumina	Chassis	Parking Brake Control Module																																																								
W	2014	Lumina	Chassis	Power Steering Control Module																																																								
W	2014	Lumina	Chassis	Steering Wheel Angle Sensor Module																																																								
W	2014	Lumina	Chassis	Suspension Control Module																																																								
W	2014	Lumina	Body	Body Control Module Coupe																																																								
W	2014	Lumina	Body	Body Control Module Sedan																																																								
W	2014	Lumina	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
W	2014	Lumina	Body	Instrument Cluster																																																								
W	2014	Lumina	Body	Head-Up Display Module																																																								
W	2014	Lumina	Body	Radio Control																																																								
W	2014	Lumina	Body	HVAC Control																																																								
W	2014	Lumina	Body	Headlamp Control Module																																																								
W	2014	Lumina	Body	Trailer Interface Control Module																																																								
W	2014	Lumina	Body	Radio																																																								
W	2014	Lumina	Body	HVAC Control Module																																																								
W	2014	Lumina	Body	Keyless Entry Control Module																																																								
W	2014	Lumina	Body	Right Side Object Detection Control Module																																																								
W	2014	Lumina	Body	Left Side Object Detection Control Module																																																								
W	2014	Lumina	Body	Parking Assist Control Module																																																								
W	2014	Lumina	Body	Frontview Camera Module																																																								
W	2014	Lumina	Body	Steering Column Lock Control Module																																																								
W	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
W	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
W	2015	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																								
W	2015	Impala	Chassis	Electronic Brake Control Module																																																								
W	2015	Impala	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V	V											
W	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
W	2015	Impala	Body	Passenger Presence Module																																																	V							
W	2015	Impala	Body	Instrument Cluster																																																								
W	2015	Impala	Body	Radio																																																								
W	2015	Impala	Body	Digital Radio Receiver Control Module																																																								
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 9																																																								
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 10																																																								
W	2015	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																		V	V						
W	2015	Impala	Body	HVAC Manual Control Single Zone (C67)																																																		V	V						
W	2015	Impala	Body	Front Seat Heating Control Module																																																								
W	2015	Impala	Body	Remote Control Door Lock Receiver																																																								
W	2015	Impala	Body	Theft Deterrent Module																																																								
W	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
W	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
W	2016	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																												
W	2016	Impala	Chassis	Electronic Brake Control Module																																																												
W	2016	Impala	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V														
W	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
W	2016	Impala	Body	Passenger Presence Module																																															V										
W	2016	Impala	Body	Instrument Cluster																																																										
W	2016	Impala	Body	Radio																																																										
W	2016	Impala	Body	Digital Radio Receiver Control Module																																																										
W	2016	Impala	Body	Telematics Communication Interface Control Module																																																										
W	2016	Impala	Body	HVAC Manual Control Dual Zone (CJ2)																																																V	V								
W	2016	Impala	Body	HVAC Manual Control Single Zone (C67)																																																V	V								
W	2016	Impala	Body	Front Seat Heating Control Module																																																										
W	2016	Impala	Body	Remote Control Door Lock Receiver																																																										
W	2016	Impala	Body	Theft Deterrent Module																																																										
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Auto																																																										
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Manual																																																										
Y	2004	ALL	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																										
Y	2004	ALL	Powertrain	Transmission Control Module																																																										
Y	2004	ALL	Chassis	RTD																																																									
Y	2004	ALL	Body	Body Control Module																																																									
Y	2004	ALL	Body	Heating and Air Conditioning																																																										
Y	2004	ALL	Body	Instrument Panel Cluster																																																										
Y	2004	ALL	Body	Left Door Control Module																																																										
Y	2004	ALL	Body	Radio																																																										
Y	2004	ALL	Body	Remote Function Actuation																																																										
Y	2004	ALL	Body	Right Door Control Module																																																										
Y	2004	ALL	Body	Seat Control Module																																																										
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2005	ALL	Powertrain	Engine Control Module																																																										
Y	2005	ALL	Powertrain	Transmission Control Module																																																										
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2005	ALL	Chassis	Electronic Suspension Control																																																										
Y	2005	ALL	Chassis	Steering Wheel and Column																																																										
Y	2005	ALL	Body	Amplifier																																																									
Y	2005	ALL	Body	Body Control Module																																																									
Y	2005	ALL	Body	Digital Radio Receiver																																																										
Y	2005	ALL	Body	Driver Door Module																																																									
Y	2005	ALL	Body	Driver Door Switch																																																									
Y	2005	ALL	Body	Driver Position Module																																																									
Y	2005	ALL	Body	Folding Top Module																																																									
Y	2005	ALL	Body	Head Up Display																																																									
Y	2005	ALL	Body	HVAC Control Module																																																									
Y	2005	ALL	Body	Instrument Panel Cluster																																																										
Y	2005	ALL	Body	Navigation Radio																																																									
Y	2005	ALL	Body	Passenger Door Module																																																									
Y	2005	ALL	Body	Radio																																																									
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																									
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2006	ALL	Powertrain	Engine Control Module																																																									
Y	2006	ALL	Powertrain	Exhaust Flow Control Module																																																									
Y	2006	ALL	Powertrain	Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Y	2006	ALL	Chassis	Electronic Brake Control Module																																																														
Y	2006	ALL	Chassis	Electronic Suspension Control																																																														
Y	2006	ALL	Chassis	Steering Wheel and Column																																																														
Y	2006	ALL	Body	Body Control Module																																																														
Y	2006	ALL	Body	CD Changer																																																														
Y	2006	ALL	Body	Digital Radio Receiver																																																														
Y	2006	ALL	Body	Driver Door Module																																																														
Y	2006	ALL	Body	Driver Door Switch																																																														
Y	2006	ALL	Body	Driver Position Module																																																														
Y	2006	ALL	Body	Folding Top Module																																																														
Y	2006	ALL	Body	Head Up Display																																																														
Y	2006	ALL	Body	HVAC Control Module																																																														
Y	2006	ALL	Body	Instrument Panel Cluster																																																														
Y	2006	ALL	Body	Navigation Radio																																																														
Y	2006	ALL	Body	Passenger Door Module																																																														
Y	2006	ALL	Body	Radio																																																														
Y	2006	ALL	Body	Remote Control Door Lock Receiver																																																														
Y	2006	ALL	Body	Supplemental Inflatable Restraint																																																														
Y	2007	ALL	Powertrain	Engine Control Module																																																														
Y	2007	ALL	Powertrain	Exhaust Flow Control Module																																																														
Y	2007	ALL	Powertrain	Transmission Control Module																																																														
Y	2007	ALL	Chassis	Electronic Brake Control Module																																																														
Y	2007	ALL	Chassis	Electronic Suspension Control																																																														
Y	2007	ALL	Body	Body Control Module																																																														
Y	2007	ALL	Body	CD Changer																																																														
Y	2007	ALL	Body	Digital Radio Receiver																																																														
Y	2007	ALL	Body	Driver Door Module																																																														
Y	2007	ALL	Body	Driver Door Switch																																																														
Y	2007	ALL	Body	Driver Position Module																																																														
Y	2007	ALL	Body	Folding Top Module																																																														
Y	2007	ALL	Body	Head Up Display																																																														
Y	2007	ALL	Body	HVAC Control Module																																																														
Y	2007	ALL	Body	Instrument Panel Cluster																																																														
Y	2007	ALL	Body	Navigation Radio																																																														
Y	2007	ALL	Body	Passenger Door Module																																																														
Y	2007	ALL	Body	Radio																																																														
Y	2007	ALL	Body	Remote Control Door Lock Receiver																																																														
Y	2007	ALL	Body	Steering Column Lock Module																																																														
Y	2007	ALL	Body	Supplemental Inflatable Restraint																																																														
Y	2008	ALL	Powertrain	Engine Control Module																																																														
Y	2008	ALL	Powertrain	Exhaust Flow Control Module																																																														
Y	2008	ALL	Powertrain	Transmission Control Module																																																														
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																														
Y	2008	ALL	Chassis	Electronic Suspension Control																																																														
Y	2008	ALL	Body	Body Control Module																																																														
Y	2008	ALL	Body	CD Changer																																																														
Y	2008	ALL	Body	Digital Radio Receiver																																																														
Y	2008	ALL	Body	Driver Door Module																																																														
Y	2008	ALL	Body	Driver Door Switch																																																														
Y	2008	ALL	Body	Driver Position Module																																																														
Y	2008	ALL	Body	Folding Top Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Y	2008	ALL	Body	Head Up Display																																																													
Y	2008	ALL	Body	HVAC Control Module																																																													
Y	2008	ALL	Body	Instrument Panel Cluster																																																													
Y	2008	ALL	Body	Navigation Radio																																																													
Y	2008	ALL	Body	Passenger Door Module																																																													
Y	2008	ALL	Body	Radio																																																													
Y	2008	ALL	Body	Personal Audio Link Module																																																													
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																													
Y	2008	ALL	Body	Steering Column Lock Module																																																													
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																													
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module										V																																																			
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																													
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																													
Y	2009	ALL	Chassis	Electronic Brake Control Module			V																																																										
Y	2009	ALL	Chassis	Electronic Suspension Control																																																													
Y	2009	ALL	Body	Body Control Module																																																													
Y	2009	ALL	Body	CD Changer																																																													
Y	2009	ALL	Body	Digital Radio Receiver																																																													
Y	2009	ALL	Body	Driver Door Module																																																													
Y	2009	ALL	Body	Driver Door Switch																																																													
Y	2009	ALL	Body	Driver Position Module																																																													
Y	2009	ALL	Body	Folding Top Module																																																													
Y	2009	ALL	Body	Head Up Display																																																													
Y	2009	ALL	Body	HVAC Control Module																																																													
Y	2009	ALL	Body	Instrument Panel Cluster																																																													
Y	2009	ALL	Body	Navigation Radio																																																													
Y	2009	ALL	Body	Passenger Door Module																																																													
Y	2009	ALL	Body	Radio																																																													
Y	2009	ALL	Body	Personal Audio Link Module																																																													
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																																													
Y	2009	ALL	Body	Steering Column Lock Module																																																													
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																													
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module										V																																																			
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																													
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																													
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module										V																																																			
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																													
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																													
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module										V																																																			
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																													
Y	2010	ALL	Chassis	Electronic Brake Control Module			V																																																										
Y	2010	ALL	Chassis	Electronic Suspension Control																																																													
Y	2010	ALL	Body	Body Control Module																																																													
Y	2010	ALL	Body	CD Changer																																																													
Y	2010	ALL	Body	Digital Radio Receiver																																																													
Y	2010	ALL	Body	Driver Door Module																																																													
Y	2010	ALL	Body	Driver Door Switch																																																													
Y	2010	ALL	Body	Driver Position Module																																																													
Y	2010	ALL	Body	Folding Top Module																																																													
Y	2010	ALL	Body	Head Up Display																																																													
Y	2010	ALL	Body	HVAC Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Y	2010	ALL	Body	Instrument Panel Cluster																																																													
Y	2010	ALL	Body	Navigation Radio																																																													
Y	2010	ALL	Body	Passenger Door Module																																																												
Y	2010	ALL	Body	Radio																																																												
Y	2010	ALL	Body	Personal Audio Link Module																																																												
Y	2010	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2010	ALL	Body	Steering Column Lock Module																																																												
Y	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module										V																																																		
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																												
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																												
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module										V																																																		
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																												
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																												
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module										V																																																		
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																												
Y	2011	ALL	Chassis	Electronic Brake Control Module			V																																																										
Y	2011	ALL	Chassis	Electronic Suspension Control																																																													
Y	2011	ALL	Body	Body Control Module																																																												
Y	2011	ALL	Body	CD Changer																																																												
Y	2011	ALL	Body	Digital Radio Receiver																																																												
Y	2011	ALL	Body	Driver Door Module																																																												
Y	2011	ALL	Body	Driver Door Switch																																																												
Y	2011	ALL	Body	Driver Position Module																																																												
Y	2011	ALL	Body	Folding Top Module																																																												
Y	2011	ALL	Body	Head Up Display																																																												
Y	2011	ALL	Body	HVAC Control Module																																																												
Y	2011	ALL	Body	Instrument Panel Cluster																																																												
Y	2011	ALL	Body	Navigation Radio																																																												
Y	2011	ALL	Body	Passenger Door Module																																																												
Y	2011	ALL	Body	Radio																																																												
Y	2011	ALL	Body	Personal Audio Link Module																																																												
Y	2011	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2011	ALL	Body	Steering Column Lock Module																																																												
Y	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module										V																																																		
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																												
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																												
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module										V																																																		
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																												
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																												
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module										V																																																		
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																												
Y	2012	ALL	Chassis	Electronic Brake Control Module			V																																																									
Y	2012	ALL	Chassis	Electronic Suspension Control																																																												
Y	2012	ALL	Body	Body Control Module																																																												
Y	2012	ALL	Body	CD Changer																																																												
Y	2012	ALL	Body	Digital Radio Receiver																																																												
Y	2012	ALL	Body	Driver Door Module																																																												
Y	2012	ALL	Body	Driver Door Switch																																																												
Y	2012	ALL	Body	Driver Position Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Y	2012	ALL	Body	Folding Top Module																																																													
Y	2012	ALL	Body	Head Up Display																																																													
Y	2012	ALL	Body	HVAC Control Module																																																													
Y	2012	ALL	Body	Instrument Panel Cluster																																																													
Y	2012	ALL	Body	Navigation Radio																																																													
Y	2012	ALL	Body	Passenger Door Module																																																													
Y	2012	ALL	Body	Radio																																																													
Y	2012	ALL	Body	Personal Audio Link Module																																																													
Y	2012	ALL	Body	Remote Control Door Lock Receiver																																																													
Y	2012	ALL	Body	Steering Column Lock Module																																																													
Y	2012	ALL	Body	Supplemental Inflatable Restraint																																																													
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module										V																																																			
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																													
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																													
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module										V																																																			
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																													
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																													
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module										V																																																			
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																													
Y	2013	ALL	Chassis	Electronic Brake Control Module			V																																																										
Y	2013	ALL	Chassis	Electronic Suspension Control																																																													
Y	2013	ALL	Body	Body Control Module																																																													
Y	2013	ALL	Body	CD Changer																																																													
Y	2013	ALL	Body	Digital Radio Receiver																																																													
Y	2013	ALL	Body	Driver Door Module																																																													
Y	2013	ALL	Body	Driver Door Switch																																																													
Y	2013	ALL	Body	Driver Position Module																																																													
Y	2013	ALL	Body	Folding Top Module																																																													
Y	2013	ALL	Body	Head Up Display																																																													
Y	2013	ALL	Body	HVAC Control Module																																																													
Y	2013	ALL	Body	Instrument Panel Cluster																																																													
Y	2013	ALL	Body	Navigation Radio																																																													
Y	2013	ALL	Body	Passenger Door Module																																																													
Y	2013	ALL	Body	Radio																																																													
Y	2013	ALL	Body	Personal Audio Link Module																																																													
Y	2013	ALL	Body	Remote Control Door Lock Receiver																																																													
Y	2013	ALL	Body	Steering Column Lock Module																																																													
Y	2013	ALL	Body	Supplemental Inflatable Restraint																																																													
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																													
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																													
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																													
Y	2014	Corvette	Powertrain	Chassis Control Module																																																													
Y	2014	Corvette	Chassis	Electronic Brake Control Module																																																													
Y	2014	Corvette	Chassis	Parking Brake Control Module																																																													
Y	2014	Corvette	Chassis	Power Steering Control Module																																																													
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																													
Y	2014	Corvette	Chassis	Suspension Control Module																																																													
Y	2014	Corvette	Body	Body Control Module Convertible																																																													
Y	2014	Corvette	Body	Body Control Module Coupe																																																													
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
Y	2014	Corvette	Body	Passenger Presence Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Y	2014	Corvette	Body	Instrument Cluster																																																													
Y	2014	Corvette	Body	Radio/HVAC Control																																																													
Y	2014	Corvette	Body	Inside Rearview Mirror																																																												
Y	2014	Corvette	Body	Radio																																																												
Y	2014	Corvette	Body	Amplifier																																																												
Y	2014	Corvette	Body	Human Machine Interface Control Module																																																												
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																												
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																												
Y	2014	Corvette	Body	HVAC Control Module																																																												
Y	2014	Corvette	Body	Seat Memory Control Module - Passenger																																																												
Y	2014	Corvette	Body	Seat Memory Control Module - Driver																																																										V	V
Y	2014	Corvette	Body	Folding Top Control Module																																																												
Y	2014	Corvette	Body	Keyless Entry Control Module																																																												
Y	2014	Corvette	Body	Steering Column Lock Control Module																																																												
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																												
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																												
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																												
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Automatic Transmission																																																												
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Manual Transmission																																																												
Y	2015	Corvette	Powertrain	6.2L LT4 Transmission Control Module																																																												
Y	2015	Corvette	Powertrain	Chassis Control Module																																																												
Y	2015	Corvette	Chassis	Electronic Brake Control Module																																																												
Y	2015	Corvette	Chassis	Parking Brake Control Module																																																												
Y	2015	Corvette	Chassis	Power Steering Control Module																																																												
Y	2015	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																												
Y	2015	Corvette	Chassis	Suspension Control Module																																																												
Y	2015	Corvette	Body	Body Control Module Convertible																																																												
Y	2015	Corvette	Body	Body Control Module Coupe																																																												
Y	2015	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
Y	2015	Corvette	Body	Passenger Presence Module																																																												
Y	2015	Corvette	Body	Instrument Cluster																																																												
Y	2015	Corvette	Body	Radio/HVAC Control																																																												
Y	2015	Corvette	Body	Vehicle Performance Data Recorder																																																												
Y	2015	Corvette	Body	Inside Rearview Mirror																																																												
Y	2015	Corvette	Body	Radio																																																											
Y	2015	Corvette	Body	Amplifier																																																											
Y	2015	Corvette	Body	Human Machine Interface Control Module																																																												
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																												
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																												
Y	2015	Corvette	Body	HVAC Control Module																																																												
Y	2015	Corvette	Body	Seat Memory Control Module - Passenger																																																												
Y	2015	Corvette	Body	Seat Memory Control Module - Driver																																																												
Y	2015	Corvette	Body	Folding Top Control Module																																																												
Y	2015	Corvette	Body	Keyless Entry Control Module																																																												
Y	2015	Corvette	Body	Steering Column Lock Control Module																																																												
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																											
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																											
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Automatic Transmission																																																											
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Manual Transmission																																																											
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Y	2016	Corvette	Powertrain	Rear Differential Clutch Control Module																																																														
Y	2016	Corvette	Chassis	Electronic Brake Control Module																																																														
Y	2016	Corvette	Chassis	Parking Brake Control Module																																																														
Y	2016	Corvette	Chassis	Power Steering Control Module																																																														
Y	2016	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																														
Y	2016	Corvette	Chassis	Suspension Control Module																																																														
Y	2016	Corvette	Body	Body Control Module																																																														
Y	2016	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
Y	2016	Corvette	Body	Passenger Presence Module																																																														
Y	2016	Corvette	Body	Instrument Cluster																																																														
Y	2016	Corvette	Body	Radio/HVAC Control																																																														
Y	2016	Corvette	Body	Vehicle Performance Data Recorder																																																														
Y	2016	Corvette	Body	Video Processing Control Module																																																														
Y	2016	Corvette	Body	Inside Rearview Mirror																																																														
Y	2016	Corvette	Body	Radio																																																														
Y	2016	Corvette	Body	Amplifier																																																														
Y	2016	Corvette	Body	Human Machine Interface Control Module																																																														
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																														
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																														
Y	2016	Corvette	Body	HVAC Control Module																																																														
Y	2016	Corvette	Body	Liftgate Control Module																																																								V	V					
Y	2016	Corvette	Body	Seat Memory Control Module - Passenger																																																													
Y	2016	Corvette	Body	Seat Memory Control Module - Driver																																																													
Y	2016	Corvette	Body	Folding Top Control Module																																																													
Y	2016	Corvette	Body	Keyless Entry Control Module																																																													
Y	2016	Corvette	Body	Steering Column Lock Control Module																																																													
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																													
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																													
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																													
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																													
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																													
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																													
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																													
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																													
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																													
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																													
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																													
Y	2016	Cruze	Chassis	Electronic Brake Control Module																																																													
Y	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																													
Y	2016	Cruze	Chassis	Power Steering Control Module																																																													
Y	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
Y	2016	Cruze	Body	Body Control Module																																																													
Y	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
Y	2016	Cruze	Body	Passenger Presence Module																																																													
Y	2016	Cruze	Body	Instrument Cluster																																																													
Y	2016	Cruze	Body	Radio Controls																																																													
Y	2016	Cruze	Body	HVAC Controls																																																													
Y	2016	Cruze	Body	Trailer Interface Control Module																																																													
Y	2016	Cruze	Body	Radio Base (IO3 IO7)																																																													
Y	2016	Cruze	Body	Radio (IOA)																																																													
Y	2016	Cruze	Body	Radio (IOB)																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Y	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																													
Y	2016	Cruze	Body	Amplifier																																																													
Y	2016	Cruze	Body	Multimedia Player Interface Module																																																													
Y	2016	Cruze	Body	Human Machine Interface Control Module																																																													
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																													
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																													
Y	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
Y	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																													
Y	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																													
Y	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																													
Y	2016	Cruze	Body	Keyless Entry Control Module																																																													
Y	2016	Cruze	Body	Right Side Object Detection Control Module																																																												
Y	2016	Cruze	Body	Left Side Object Detection Control Module																																																												
Y	2016	Cruze	Body	Parking Assist Control Module																																																												
Y	2016	Cruze	Body	Frontview Camera Module																																																												
Y	2016	Cruze	Body	Steering Column Lock Control Module																																																												
Y	2016	Cruze	Body	Long Range Radar Sensor Module																																																												
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																												
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Transmission Control Module																																																												
Z	2004	ALL	Chassis	Electronic Brake Control Module																																																												
Z	2004	ALL	Chassis	Power Steering Control Module																																																												
Z	2004	ALL	Body	Body Control Module																																																												
Z	2004	ALL	Body	Digital Radio Receiver																																																												
Z	2004	ALL	Body	HVAC Control Module																																																												
Z	2004	ALL	Body	Instrument Panel Cluster																																																												
Z	2004	ALL	Body	Radio																																																												
Z	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
Z	2004	ALL	Body	Theft Deterrent Module							V																																																				
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
Z	2005	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																												
Z	2005	ALL	Chassis	Electronic Brake Control Module																																																												
Z	2005	ALL	Chassis	Power Steering Control Module																																																												
Z	2005	ALL	Body	Body Control Module																																																												
Z	2005	ALL	Body	Digital Radio Receiver																																																												
Z	2005	ALL	Body	HVAC Control Module																																																												
Z	2005	ALL	Body	Instrument Panel Cluster																																																												
Z	2005	ALL	Body	Radio																																																												
Z	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
Z	2005	ALL	Body	Theft Deterrent Module							V																																																				
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
Z	2006	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																												
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																												
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																												
Z	2006	ALL	Chassis	Electronic Brake Control Module																																																												
Z	2006	ALL	Chassis	Power Steering Control Module																																																												
Z	2006	ALL	Body	Body Control Module																																																												
Z	2006	ALL	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Z	2006	ALL	Body	HVAC Control Module																																																														
Z	2006	ALL	Body	Instrument Panel Cluster																																																														
Z	2006	ALL	Body	Radio																																																													
Z	2006	ALL	Body	Supplemental Inflatable Restraint																																																													
Z	2006	ALL	Body	Theft Deterrent Module							V																																																						
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																														
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																														
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																														
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																														
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																														
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																														
Z	2007	ALL	Chassis	Electronic Brake Control Module																																																														
Z	2007	ALL	Chassis	Power Steering Control Module																																																														
Z	2007	ALL	Body	Body Control Module																																																														
Z	2007	ALL	Body	Digital Radio Receiver																																																														
Z	2007	ALL	Body	Disc Player and Video Display																																																														
Z	2007	ALL	Body	HVAC Control Module																																																														
Z	2007	ALL	Body	Instrument Panel Cluster																																																														
Z	2007	ALL	Body	Radio																																																														
Z	2007	ALL	Body	Remote Control Door Lock Receiver																																																														
Z	2007	ALL	Body	Supplemental Inflatable Restraint																																																														
Z	2007	ALL	Body	Theft Deterrent Module							V																																																						
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																														
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																														
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																														
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																														
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																														
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																														
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																														
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																														
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
Z	2008	ALL	Chassis	Electronic Brake Control Module																																																														
Z	2008	ALL	Chassis	Power Steering Control Module																																																														
Z	2008	ALL	Body	Body Control Module Classic																																																														
Z	2008	ALL	Body	Body Control Module Malibu																																																														
Z	2008	ALL	Body	Digital Radio Receiver																																																														
Z	2008	ALL	Body	Disc Player and Video Display																																																														
Z	2008	ALL	Body	HVAC Control Module Classic																																																														
Z	2008	ALL	Body	HVAC Control Module Malibu																																																														
Z	2008	ALL	Body	Instrument Panel Cluster Classic																																																														
Z	2008	ALL	Body	Instrument Panel Cluster Malibu																																																														
Z	2008	ALL	Body	Radio																																																														
Z	2008	ALL	Body	Remote Control Door Lock Receiver																																																														
Z	2008	ALL	Body	Supplemental Inflatable Restraint																																																														
Z	2008	ALL	Body	Theft Deterrent Module							V																																																						
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module										V																																																			
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																														
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																														
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump																																																													
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump																																																													
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Without Tap Shift																																																													
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																													
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																													
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
Z	2009	ALL	Chassis	Electronic Brake Control Module																																																													
Z	2009	ALL	Chassis	Power Steering Control Module																																																													
Z	2009	ALL	Body	Body Control Module																																																													
Z	2009	ALL	Body	Digital Radio Receiver																																																													
Z	2009	ALL	Body	Disc Player and Video Display																																																													
Z	2009	ALL	Body	HVAC Control Module																																																													
Z	2009	ALL	Body	Instrument Panel Cluster																																																													
Z	2009	ALL	Body	Personal Audio Link Module																																																													
Z	2009	ALL	Body	Radio																																																													
Z	2009	ALL	Body	Supplemental Inflatable Restraint																																																													
Z	2009	ALL	Body	Theft Deterrent Module							V																																																					
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module										V																																																			
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																													
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																													
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Engine Control Module										V																																																		
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 6 Speed																																																													
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 4 Speed																																																													
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																													
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																													
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																													
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																													
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
Z	2010	ALL	Chassis	Electronic Brake Control Module																																																													
Z	2010	ALL	Chassis	Power Steering Control Module																																																													
Z	2010	ALL	Body	Body Control Module																																																													
Z	2010	ALL	Body	Digital Radio Receiver																																																													
Z	2010	ALL	Body	HVAC Control Module																																																													
Z	2010	ALL	Body	Instrument Panel Cluster																																																													
Z	2010	ALL	Body	Personal Audio Link Module																																																													
Z	2010	ALL	Body	Radio																																																													
Z	2010	ALL	Body	Supplemental Inflatable Restraint																																																													
Z	2010	ALL	Body	Theft Deterrent Module							V																																																					
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module										V																																																			
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																													
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Engine Control Module										V																																																		
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																													
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
Z	2011	ALL	Chassis	Electronic Brake Control Module																																																													
Z	2011	ALL	Chassis	Power Steering Control Module																																																													
Z	2011	ALL	Body	Body Control Module																																																													
Z	2011	ALL	Body	Digital Radio Receiver																																																													
Z	2011	ALL	Body	HVAC Control Module																																																													
Z	2011	ALL	Body	Instrument Panel Cluster																																																													
Z	2011	ALL	Body	Personal Audio Link Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Z	2011	ALL	Body	Radio																																																														
Z	2011	ALL	Body	Supplemental Inflatable Restraint																																																													
Z	2011	ALL	Body	Theft Deterrent Module							V																																																					
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Engine Control Module										V																																																			
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Transmission Control Module																																																													
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Engine Control Module										V																																																		
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																													
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Engine Control Module										V																																																			
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																													
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
Z	2012	Malibu (Seventh Gen)	Chassis	Electronic Brake Control Module																																																													
Z	2012	Malibu (Seventh Gen)	Chassis	Power Steering Control Module																																																													
Z	2012	Malibu (Seventh Gen)	Body	Body Control Module																																																													
Z	2012	Malibu (Seventh Gen)	Body	Digital Radio Receiver																																																													
Z	2012	Malibu (Seventh Gen)	Body	HVAC Control Module																																																													
Z	2012	Malibu (Seventh Gen)	Body	Instrument Panel Cluster																																																													
Z	2012	Malibu (Seventh Gen)	Body	Personal Audio Link Module																																																													
Z	2012	Malibu (Seventh Gen)	Body	Radio																																																													
Z	2012	Malibu (Seventh Gen)	Body	Supplemental Inflatable Restraint																																																													
Z	2012	Malibu (Seventh Gen)	Body	Theft Deterrent Module							V																																																					
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Fuel Injector Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Transmission Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Transmission Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Fuel Pump Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Transmission Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Fuel Pump Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Powertrain	Rear Differential Clutch Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Chassis	Electronic Brake Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Chassis	Parking Brake Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																													
Z	2012	Malibu (Eighth Gen)	Chassis	Power Steering Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Chassis	Steering Wheel Angle Sensor Module																																																													
Z	2012	Malibu (Eighth Gen)	Chassis	Suspension Control Module																																																													
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																													
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																													
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																													
Z	2012	Malibu (Eighth Gen)	Body	Passenger Presence Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Z	2012	Malibu (Eighth Gen)	Body	Instrument Cluster																																																												
Z	2012	Malibu (Eighth Gen)	Body	Head-Up Display Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Headlamp Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Radio																																																												
Z	2012	Malibu (Eighth Gen)	Body	Digital Radio Receiver Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Multimedia Player Interface Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Mobile Telephone Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Dual (CJ2)																																																												
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Single (C68)																																																												
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Manual Single (C67)																																																												
Z	2012	Malibu (Eighth Gen)	Body	Rear Seat Heating Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Keyless Entry Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Right Side Object Detection Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Left Side Object Detection Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Parking Assist Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Vehicle Direction Camera Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Steering Column Lock Control Module																																																												
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Engine Control Module																																																												
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Transmission Control Module																																																												
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Engine Control Module																																																												
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 1																																																												
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 2																																																												
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module																																																												
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 6 Speed (MNM)																																																												
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 8 Speed (MRC)																																																												
Z	2016	Malibu	Chassis	Electronic Brake Control Module																																																												
Z	2016	Malibu	Chassis	Brake Booster Control Module																																																												
Z	2016	Malibu	Chassis	Power Steering Control Module																																																												
Z	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
Z	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
Z	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
Z	2016	Malibu	Body	Passenger Presence Module																																																												
Z	2016	Malibu	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
Z	2016	Malibu	Body	Instrument Cluster Enhanced Monochrome Driver Info Center (UDC)																																																												
Z	2016	Malibu	Body	Radio Controls																																																												
Z	2016	Malibu	Body	HVAC Controls																																																												
Z	2016	Malibu	Body	Active Safety Control Module																																																												
Z	2016	Malibu	Body	Headlamp Control Module																																																												
Z	2016	Malibu	Body	Radio Base																																																												
Z	2016	Malibu	Body	Radio (IOA)																																																												
Z	2016	Malibu	Body	Radio Uplevel (IO4 IO5 IO6)																																																												
Z	2016	Malibu	Body	Amplifier																																																												
Z	2016	Malibu	Body	Human Machine Interface Control Module																																																												
Z	2016	Malibu	Body	Navigation Control Module																																																												
Z	2016	Malibu	Body	Mobile Telephone Control Module																																																												
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																												
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																												
Z	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																												
Z	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																												
Z	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																												
Z	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
Z	2016	Malibu	Body	Electric A/C Compressor Control Module																																																															
Z	2016	Malibu	Body	Seat Memory Control Module - Driver																																																															
Z	2016	Malibu	Body	Keyless Entry Control Module																																																															
Z	2016	Malibu	Body	Right Side Object Detection Control Module																																																															
Z	2016	Malibu	Body	Left Side Object Detection Control Module																																																															
Z	2016	Malibu	Body	Parking Assist Control Module																																																															
Z	2016	Malibu	Body	Frontview Camera Module																																																															
Z	2016	Malibu	Body	Frontview Camera Module																																																															
Z	2016	Malibu	Body	Steering Column Lock Control Module																																																															
Z	2016	Malibu	Body	Long Range Radar Sensor Module																																																															
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																															
1	2013	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																															
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																															
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LTD Fuel Pump Control Module																																																															
1	2013	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																															
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	(X) 2.0L LTG Fuel Pump Control Module																																																															
1	2013	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																															
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																															
1	2013	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																															
1	2013	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																															
1	2013	Malibu	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																															
1	2013	Malibu	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																																																															
1	2013	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																															
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	(A) 2.5L LCV Fuel Pump Control Module																																																															
1	2013	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																															
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																															
1	2013	Malibu	Chassis	Electronic Brake Control Module																																																															
1	2013	Malibu	Chassis	Parking Brake Control Module																																																															
1	2013	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																															
1	2013	Malibu	Chassis	Power Steering Control Module																																																															
1	2013	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																															
1	2013	Malibu	Chassis	Suspension Control Module																																																															
1	2013	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																															
1	2013	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																															
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																													
1	2013	Malibu	Body	Passenger Presence Module																																																													
1	2013	Malibu	Body	Instrument Cluster																																																													
1	2013	Malibu	Body	Headlamp Control Module																																																													
1	2013	Malibu	Body	Radio																																																													
1	2013	Malibu	Body	Digital Radio Receiver Control Module																																																													
1	2013	Malibu	Body	Multimedia Player Interface Module																																																													
1	2013	Malibu	Body	Mobile Telephone Control Module																																																													
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																													
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																													
1	2013	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																													
1	2013	Malibu	Body	HVAC Control Module Auto Single (C68)																																																													
1	2013	Malibu	Body	HVAC Control Module Manual Single (C67)																																																													
1	2013	Malibu	Body	Rear Seat Heating Control Module																																																													
1	2013	Malibu	Body	Keyless Entry Control Module																																																													
1	2013	Malibu	Body	Parking Assist Control Module																																																													
1	2013	Malibu	Body	Vehicle Direction Camera Control Module																																																													
1	2013	Malibu	Body	Steering Column Lock Control Module																																																													
1	2013	Malibu	Body	Battery Energy Control Module																																																													
1	2014	Impala	Powertrain	(R) 2.4L LUK Engine Control Module																																																													
1	2014	Impala	Powertrain	(R) 2.4L LUK Transmission Control Module																																																													
1	2014	Impala	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																													
1	2014	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																													
1	2014	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																													
1	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
1	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																													
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																													
1	2014	Impala	Chassis	Electronic Brake Control Module																																																													
1	2014	Impala	Chassis	Distance Sensing Cruise Control Module																																																													
1	2014	Impala	Chassis	Parking Brake Control Module																																																													
1	2014	Impala	Chassis	Power Steering Control Module																																																													
1	2014	Impala	Chassis	Steering Wheel Angle Sensor Module																																																													
1	2014	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																													
1	2014	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
1	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
1	2014	Impala	Body	Passenger Presence Module																																																														
1	2014	Impala	Body	Instrument Cluster																																																														
1	2014	Impala	Body	Radio Control																																																													
1	2014	Impala	Body	HVAC Control																																																													
1	2014	Impala	Body	Radio																																																													
1	2014	Impala	Body	Amplifier																																																													
1	2014	Impala	Body	Human Machine Interface Control Module																																																													
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																													
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																													
1	2014	Impala	Body	HVAC Control Module																																																													
1	2014	Impala	Body	Keyless Entry Control Module																																																													
1	2014	Impala	Body	Right Side Object Detection Control Module																																																													
1	2014	Impala	Body	Left Side Object Detection Control Module																																																													
1	2014	Impala	Body	Parking Assist Control Module																																																													
1	2014	Impala	Body	Frontview Camera Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2014	Impala	Body	Steering Column Lock Control Module																																																														
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																														
1	2014	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																														
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																														
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																														
1	2014	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																														
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																														
1	2014	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																														
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																														
1	2014	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																														
1	2014	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																														
1	2014	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																														
1	2014	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																														
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																														
1	2014	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																														
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
1	2014	Malibu	Chassis	Electronic Brake Control Module																																																														
1	2014	Malibu	Chassis	Parking Brake Control Module																																																														
1	2014	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																														
1	2014	Malibu	Chassis	Power Steering Control Module																																																														
1	2014	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																														
1	2014	Malibu	Chassis	Suspension Control Module																																																														
1	2014	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
1	2014	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																														
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																														
1	2014	Malibu	Body	Passenger Presence Module																																																														
1	2014	Malibu	Body	Instrument Cluster																																																														
1	2014	Malibu	Body	Headlamp Control Module																																																														
1	2014	Malibu	Body	Radio																																																														
1	2014	Malibu	Body	Digital Radio Receiver Control Module																																																														
1	2014	Malibu	Body	Multimedia Player Interface Module																																																														
1	2014	Malibu	Body	Mobile Telephone Control Module																																																														
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																														
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																														
1	2014	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																														
1	2014	Malibu	Body	HVAC Control Module Auto Single (C68)																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2014	Malibu	Body	HVAC Control Module Manual Single (C67)																																																														
1	2014	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																														
1	2014	Malibu	Body	Rear Seat Heating Control Module																																																														
1	2014	Malibu	Body	Keyless Entry Control Module																																																														
1	2014	Malibu	Body	Left Side Object Detection Control Module																																																														
1	2014	Malibu	Body	Parking Assist Control Module																																																														
1	2014	Malibu	Body	Frontview Camera Module																																																														
1	2014	Malibu	Body	Steering Column Lock Control Module																																																														
1	2015	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																														
1	2015	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																														
1	2015	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																														
1	2015	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																														
1	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
1	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																														
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																														
1	2015	Impala	Chassis	Electronic Brake Control Module																																																														
1	2015	Impala	Chassis	Distance Sensing Cruise Control Module																																																														
1	2015	Impala	Chassis	Parking Brake Control Module																																																														
1	2015	Impala	Chassis	Power Steering Control Module																																																														
1	2015	Impala	Chassis	Power Steering Control Module																																																														
1	2015	Impala	Chassis	Steering Wheel Angle Sensor Module																																																														
1	2015	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
1	2015	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
1	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
1	2015	Impala	Body	Passenger Presence Module																																																															
1	2015	Impala	Body	Instrument Cluster																																																															
1	2015	Impala	Body	Radio Control																																																															
1	2015	Impala	Body	HVAC Control																																																															
1	2015	Impala	Body	Radio																																																															
1	2015	Impala	Body	Amplifier																																																															
1	2015	Impala	Body	Human Machine Interface Control Module																																																															
1	2015	Impala	Body	Telematics Communication Interface Control Module																																																															
1	2015	Impala	Body	HVAC Control Module																																																															
1	2015	Impala	Body	Keyless Entry Control Module																																																															
1	2015	Impala	Body	Right Side Object Detection Control Module																																																															
1	2015	Impala	Body	Left Side Object Detection Control Module																																																															
1	2015	Impala	Body	Parking Assist Control Module																																																															
1	2015	Impala	Body	Frontview Camera Module																																																															
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																															
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																															
1	2015	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																															
1	2015	Malibu	Powertrain	2.0L LBN Chassis Control Module																																																															
1	2015	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																															
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																														
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																														
1	2015	Malibu	Powertrain	2.0L LBS Chassis Control Module																																																														
1	2015	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																															
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																														
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																														
1	2015	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2015	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																														
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																														
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																														
1	2015	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																														
1	2015	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																														
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																														
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																														
1	2015	Malibu	Powertrain	2.4L LE9 Chassis Control Module																																																														
1	2015	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																														
1	2015	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																														
1	2015	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																														
1	2015	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																														
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																														
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																														
1	2015	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																														
1	2015	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																														
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Automatic Transmission																																																														
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Manual Transmission																																																														
1	2015	Malibu	Powertrain	3.0L LFW Chassis Control Module																																																														
1	2015	Malibu	Powertrain	3.0L LFW Transmission Control Module																																																														
1	2015	Malibu	Powertrain	Rear Differential Clutch Control Module																																																														
1	2015	Malibu	Chassis	Electronic Brake Control Module																																																														
1	2015	Malibu	Chassis	Parking Brake Control Module																																																														
1	2015	Malibu	Chassis	Power Steering Control Module																																																														
1	2015	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																														
1	2015	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
1	2015	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
1	2015	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
1	2015	Malibu	Body	Passenger Presence Module																																																														
1	2015	Malibu	Body	Instrument Cluster																																																														
1	2015	Malibu	Body	Headlamp Control Module																																																														
1	2015	Malibu	Body	Radio																																																														
1	2015	Malibu	Body	Digital Radio Receiver Control Module																																																														
1	2015	Malibu	Body	Multimedia Player Interface Module																																																														
1	2015	Malibu	Body	Mobile Telephone Control Module																																																														
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																														
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																														
1	2015	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																														
1	2015	Malibu	Body	HVAC Control Module Auto Single (C68)																																																														
1	2015	Malibu	Body	HVAC Control Module Manual Single (C67)																																																														
1	2015	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																														
1	2015	Malibu	Body	Front Seat Heating Control Module																																																														
1	2015	Malibu	Body	Rear Seat Heating Control Module																																																														
1	2015	Malibu	Body	Keyless Entry Control Module																																																														
1	2015	Malibu	Body	Left Side Object Detection Control Module																																																														
1	2015	Malibu	Body	Parking Assist Control Module																																																														
1	2015	Malibu	Body	Frontview Camera Module																																																														
1	2015	Malibu	Body	Steering Column Lock Control Module																																																														
1	2015	Malibu (LSG)	Powertrain	1.6L LLU Engine Control Module																																																														
1	2015	Malibu (LSG)	Powertrain	Transmission Control Module																																																														
1	2015	Malibu (LSG)	Powertrain	Rear Differential Clutch Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2015	Malibu (LSG)	Chassis	Electronic Brake Control Module																																																														
1	2015	Malibu (LSG)	Chassis	Parking Brake Control Module																																																														
1	2015	Malibu (LSG)	Chassis	Steering Wheel Angle Sensor Module																																																														
1	2015	Malibu (LSG)	Chassis	Suspension Control Module																																																														
1	2015	Malibu (LSG)	Body	Body Control Module																																																														
1	2015	Malibu (LSG)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
1	2015	Malibu (LSG)	Body	Instrument Cluster																																																														
1	2015	Malibu (LSG)	Body	Headlamp Control Module																																																														
1	2015	Malibu (LSG)	Body	Radio																																																														
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 9.7																																																														
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 10																																																														
1	2015	Malibu (LSG)	Body	HVAC Control Module																																																														
1	2015	Malibu (LSG)	Body	Front Seat Heating Control Module																																																														
1	2015	Malibu (LSG)	Body	Keyless Entry Control Module																																																														
1	2015	Malibu (LSG)	Body	Left Side Object Detection Control Module																																																														
1	2015	Malibu (LSG)	Body	Parking Assist Control Module																																																														
1	2015	Malibu (LSG)	Body	Frontview Camera Module																																																														
1	2015	Malibu (LSG)	Body	Steering Column Lock Control Module																																																														
1	2016	Impala	Powertrain	(A) 2.5L LCV Engine Control Module																																																														
1	2016	Impala	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														
1	2016	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																														
1	2016	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																														
1	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
1	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
1	2016	Impala	Powertrain	Chassis Control Module																																																														
1	2016	Impala	Chassis	Electronic Brake Control Module																																																														
1	2016	Impala	Chassis	Distance Sensing Cruise Control Module																																																														
1	2016	Impala	Chassis	Parking Brake Control Module																																																														
1	2016	Impala	Chassis	Power Steering Control Module																																																														
1	2016	Impala	Chassis	Power Steering Control Module																																																														
1	2016	Impala	Chassis	Steering Wheel Angle Sensor Module																																																														
1	2016	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
1	2016	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
1	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
1	2016	Impala	Body	Passenger Presence Module																																																														
1	2016	Impala	Body	Instrument Cluster																																																														
1	2016	Impala	Body	Radio Control																																																														
1	2016	Impala	Body	HVAC Control																																																														
1	2016	Impala	Body	Radio																																																														
1	2016	Impala	Body	Amplifier																																																														
1	2016	Impala	Body	Human Machine Interface Control Module																																																														
1	2016	Impala	Body	Navigation Control Module																																																														
1	2016	Impala	Body	Telematics Communication Interface Control Module																																																														
1	2016	Impala	Body	HVAC Control Module																																																														
1	2016	Impala	Body	Seat Memory Control Module - Driver																																																														
1	2016	Impala	Body	Keyless Entry Control Module																																																														
1	2016	Impala	Body	Right Side Object Detection Control Module																																																														
1	2016	Impala	Body	Left Side Object Detection Control Module																																																														
1	2016	Impala	Body	Parking Assist Control Module																																																														
1	2016	Impala	Body	Frontview Camera Module																																																														
1	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																													
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																													
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																													
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
1	2016	Malibu	Powertrain	Fuel Injector Control Module																																																													
1	2016	Malibu	Powertrain	Chassis Control Module																																																													
1	2016	Malibu	Chassis	Electronic Brake Control Module																																																													
1	2016	Malibu	Chassis	Parking Brake Control Module																																																													
1	2016	Malibu	Chassis	Power Steering Control Module																																																													
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																													
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																													
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
1	2016	Malibu	Body	Passenger Presence Module																																																													
1	2016	Malibu	Body	Instrument Cluster																																																													
1	2016	Malibu	Body	Headlamp Control Module																																																													
1	2016	Malibu	Body	Radio																																																													
1	2016	Malibu	Body	Digital Radio Receiver Control Module																																																													
1	2016	Malibu	Body	Multimedia Player Interface Module																																																													
1	2016	Malibu	Body	Mobile Telephone Control Module																																																													
1	2016	Malibu	Body	Telematics Communication Interface Control Module																																																													
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																													
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																													
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																													
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																													
1	2016	Malibu	Body	Seat Memory Control Module																																																													
1	2016	Malibu	Body	Front Seat Heating Control Module																																																													
1	2016	Malibu	Body	Rear Seat Heating Control Module																																																													
1	2016	Malibu	Body	Keyless Entry Control Module																																																													
1	2016	Malibu	Body	Left Side Object Detection Control Module																																																													
1	2016	Malibu	Body	Parking Assist Control Module																																																													
1	2016	Malibu	Body	Frontview Camera Module																																																													

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2005	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																									
A	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
A	2005	ALL	Powertrain	Transmission Control Module																																																									
A	2005	ALL	Chassis	Power Steering Control Module																																																									
A	2005	ALL	Chassis	Anti-lock Brake System																																																									
A	2005	ALL	Body	Body Control Module																																																								
A	2005	ALL	Body	Digital Radio Receiver																																																								
A	2005	ALL	Body	Instrument Panel																																																								
A	2005	ALL	Body	Radio																																																								
A	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
A	2006	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																								
A	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																						V																																		
A	2006	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																								
A	2006	ALL	Powertrain	Transmission Control Module																																																								
A	2006	ALL	Chassis	Power Steering Control Module																																																								
A	2006	ALL	Chassis	Anti-lock Brake System																																																								
A	2006	ALL	Body	Body Control Module																																																								
A	2006	ALL	Body	Digital Radio Receiver																																																								
A	2006	ALL	Body	Instrument Panel																																																								
A	2006	ALL	Body	Radio																																																								
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
A	2006	ALL	Body	Theft Deterrent Module																										V	V																														
A	2007	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																								
A	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																						V																																		
A	2007	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																								
A	2007	ALL	Powertrain	Transmission Control Module																																																								
A	2007	ALL	Chassis	Power Steering Control Module																																																								
A	2007	ALL	Chassis	Electronic Brake Control Module																																																								
A	2007	ALL	Body	Body Control Module																																																								
A	2007	ALL	Body	Digital Radio Receiver																																																								
A	2007	ALL	Body	Instrument Panel Cluster																																																								
A	2007	ALL	Body	Passenger Presence System																																																								
A	2007	ALL	Body	Personal Audio Link Module																																																								
A	2007	ALL	Body	Radio																																																								
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
A	2007	ALL	Body	Theft Deterrent Module																										V	V																													
A	2008	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																								
A	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																						V																																		
A	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																								
A	2008	ALL	Powertrain	Transmission Control Module																																																								
A	2008	ALL	Chassis	Power Steering Control Module																																																								
A	2008	ALL	Chassis	Electronic Brake Control Module with VSES																																																								
A	2008	ALL	Chassis	Electronic Brake Control Module without VSES																																																								
A	2008	ALL	Body	Body Control Module																																																								
A	2008	ALL	Body	Digital Radio Receiver																																																								
A	2008	ALL	Body	Instrument Panel Cluster																																																								
A	2008	ALL	Body	Passenger Presence System																																																								
A	2008	ALL	Body	Personal Audio Link Module																																																								
A	2008	ALL	Body	Radio																																																								
A	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
A	2008	ALL	Body	Theft Deterrent Module																										V	V																													

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2009	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	ALL	Powertrain	(H)2.2L L4 LAP Engine Control Module																						V																																				
A	2009	ALL	Powertrain	Transmission Control Module																																																										
A	2009	ALL	Chassis	Power Steering Control Module																																																										
A	2009	ALL	Chassis	Electronic Brake Control Module with VSES																																																										
A	2009	ALL	Chassis	Electronic Brake Control Module without VSES																																																										
A	2009	ALL	Body	Body Control Module																																																										
A	2009	ALL	Body	Digital Radio Receiver																																																										
A	2009	ALL	Body	Instrument Panel Cluster																																																										
A	2009	ALL	Body	Passenger Presence System																																																										
A	2009	ALL	Body	Personal Audio Link Module																																																										
A	2009	ALL	Body	Radio																																																										
A	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2009	ALL	Body	Theft Deterrent Module																										V	V																															
A	2010	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2010	ALL	Powertrain	(5)2.2L L4 LAP Engine Control Module																						V																																				
A	2010	ALL	Powertrain	Transmission Control Module																																																										
A	2010	ALL	Chassis	Power Steering Control Module																																																										
A	2010	ALL	Chassis	Electronic Brake Control Module with VSES																																																										
A	2010	ALL	Chassis	Electronic Brake Control Module without VSES																																																										
A	2010	ALL	Body	Body Control Module																																																										
A	2010	ALL	Body	Digital Radio Receiver																																																										
A	2010	ALL	Body	Driver Information Center																																																										
A	2010	ALL	Body	Instrument Panel Cluster																																																										
A	2010	ALL	Body	Passenger Presence System																																																										
A	2010	ALL	Body	Personal Audio Link Module																																																										
A	2010	ALL	Body	Radio																																																										
A	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2010	ALL	Body	Theft Deterrent Module																										V	V																															
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																										
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
A	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																										
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2012	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																										
A	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2012	Cobalt	Body	Body Control Module																																																										
A	2012	Cobalt	Body	Passenger Presence Module																																																										
A	2012	Cobalt	Body	Instrument Cluster																																																										
A	2012	Cobalt	Body	Radio																																																										
A	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
A	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																										
A	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2012	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2012	Cobalt	Body	Parking Assist Control Module																																																										
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2013	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	Cobalt	Body	Body Control Module																																																										
A	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	Cobalt	Body	Instrument Cluster																																																										
A	2013	Cobalt	Body	Radio																																																										
A	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																										
A	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
A	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2013	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2013	Cobalt	Body	Parking Assist Control Module																																																										
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2014	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	Cobalt	Body	Body Control Module																																																										
A	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	Cobalt	Body	Instrument Cluster																																																										
A	2014	Cobalt	Body	Radio																																																										
A	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2014	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2014	Cobalt	Body	Parking Assist Control Module																																																										
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2015	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	Cobalt	Body	Body Control Module																																																										
A	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	Cobalt	Body	Instrument Cluster																																																										
A	2015	Cobalt	Body	Radio																																																										
A	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																										
A	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
A	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2015	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2015	Cobalt	Body	Parking Assist Control Module																																																										
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2016	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	Cobalt	Body	Body Control Module																																																										
A	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	Cobalt	Body	Instrument Cluster																																																										
A	2016	Cobalt	Body	Radio Other																																																										
A	2016	Cobalt	Body	Radio (IOB)																																																										
A	2016	Cobalt	Body	Radio (UF7)																																																										
A	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2016	Cobalt	Body	Front Seat Heating Control Module																																																										
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																										
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																										
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module										V																																																
B	2010	Beat	Powertrain	Transmission Control Module																																																										
B	2010	Beat	Chassis	Electronic Brake Control Module																																																										
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2010	Beat	Chassis	Power Steering Control Module																																																										
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2010	Beat	Body	Instrument Cluster																																																										
B	2010	Beat	Body	Keyless Entry Control Module						V																																																				
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																										
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																										
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module										V																																																
B	2011	Beat	Powertrain	Transmission Control Module																																																										
B	2011	Beat	Chassis	Electronic Brake Control Module																																																										
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2011	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2011	Beat	Body	Instrument Cluster																																																										
B	2011	Beat	Body	Keyless Entry Control Module						V																																																				
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module										V																																																
B	2012	Beat	Powertrain	Transmission Control Module																																																										
B	2012	Beat	Chassis	Electronic Brake Control Module																																																										
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2012	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2012	Beat	Body	Instrument Cluster																																																										
B	2012	Beat	Body	Keyless Entry Control Module						V																																																				
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module										V																																																
B	2013	Beat	Powertrain	Transmission Control Module																																																										
B	2013	Beat	Chassis	Electronic Brake Control Module																																																										
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2013	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2013	Beat	Body	Instrument Cluster																																																										
B	2013	Beat	Body	Keyless Entry Control Module						V																																																				
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module										V																																																
B	2014	Beat	Powertrain	Transmission Control Module																																																										
B	2014	Beat	Powertrain	Fuel Injector Control Module																																																										
B	2014	Beat	Chassis	Electronic Brake Control Module																																																										
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
B	2014	Beat	Chassis	Power Steering Control Module																																																										
B	2014	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2014	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2014	Beat	Body	Instrument Cluster																																																										
B	2014	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2015	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2015	Beat	Powertrain	1.19L LC5 Engine Control Module										V																																															
B	2015	Beat	Powertrain	Transmission Control Module																																																										
B	2015	Beat	Powertrain	Fuel Injector Control Module																																																										
B	2015	Beat	Chassis	Electronic Brake Control Module																																																										
B	2015	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2015	Beat	Chassis	Power Steering Control Module																																																										
B	2015	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2015	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2015	Beat	Body	Instrument Cluster																																																										
B	2015	Beat	Body	Radio																																																										
B	2015	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2015	Beat	Body	Keyless Entry Control Module						V																																																				
B	2016	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2016	Beat	Powertrain	1.19L LC5 Engine Control Module										V																																															
B	2016	Beat	Powertrain	Transmission Control Module																																																										
B	2016	Beat	Chassis	Electronic Brake Control Module																																																										
B	2016	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2016	Beat	Chassis	Power Steering Control Module																																																										
B	2016	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2016	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2016	Beat	Body	Instrument Cluster																																																										
B	2016	Beat	Body	Radio																																																										
B	2016	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2016	Beat	Body	HVAC Control Module																																																										
B	2016	Beat	Body	Keyless Entry Control Module						V																																																				
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																										
B	2016	Cruze	Chassis	Electronic Brake Control Module																																		V	V																							
B	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																										
B	2016	Cruze	Chassis	Power Steering Control Module																																																										
B	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2016	Cruze	Body	Body Control Module																																																										
B	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2016	Cruze	Body	Passenger Presence Module																																																										
B	2016	Cruze	Body	Instrument Cluster																																																										
B	2016	Cruze	Body	Radio Controls																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
B	2016	Cruze	Body	HVAC Controls																																																										
B	2016	Cruze	Body	Trailer Interface Control Module																																																											
B	2016	Cruze	Body	Radio Base (IO3 IO7)																																																											
B	2016	Cruze	Body	Radio (IOA)																																																											
B	2016	Cruze	Body	Radio (IOB)																																																											
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																											
B	2016	Cruze	Body	Amplifier																																																											
B	2016	Cruze	Body	Multimedia Player Interface Module																																																											
B	2016	Cruze	Body	Human Machine Interface Control Module																																																											
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																											
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																											
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																											
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																											
B	2016	Cruze	Body	Keyless Entry Control Module																																																											
B	2016	Cruze	Body	Right Side Object Detection Control Module																																																											
B	2016	Cruze	Body	Left Side Object Detection Control Module																																																											
B	2016	Cruze	Body	Parking Assist Control Module																																																											
B	2016	Cruze	Body	Frontview Camera Module																																																											
B	2016	Cruze	Body	Steering Column Lock Control Module																																																											
B	2016	Cruze	Body	Long Range Radar Sensor Module																																																											
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module										V																																																
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
C	2010	Spark	Powertrain	Transmission Control Module																																																											
C	2010	Spark	Chassis	Electronic Brake Control Module																																																											
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2010	Spark	Chassis	Electric Power Steering Control Module																																																											
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2010	Spark	Body	Passenger Presence Module																																																											
C	2010	Spark	Body	Instrument Cluster																																																											
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module										V																																																
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module										V																																																
C	2011	Spark	Powertrain	Transmission Control Module																																																											
C	2011	Spark	Chassis	Electronic Brake Control Module																																																											
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2011	Spark	Chassis	Electric Power Steering Control Module																																																											
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2011	Spark	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2011	Spark	Body	Instrument Cluster																																																										
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module										V																																																
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module										V																																																
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module										V																																																
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module										V																																																
C	2012	Spark	Powertrain	Transmission Control Module																																																											
C	2012	Spark	Chassis	Electronic Brake Control Module																																																											
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2012	Spark	Chassis	Electric Power Steering Control Module																																																											
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2012	Spark	Body	Passenger Presence Module																																																											
C	2012	Spark	Body	Instrument Cluster																																																											
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																	
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module										V																																																	
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module										V																																																	
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																											
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module										V																																																	
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																											
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																	
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2013	Spark	Powertrain	Fuel Injector Control Module																																																											
C	2013	Spark	Chassis	Electronic Brake Control Module																																																											
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2013	Spark	Chassis	Power Steering Control Module																																																											
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2013	Spark	Body	Body Control Module																																																											
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2013	Spark	Body	Passenger Presence Module																																																											
C	2013	Spark	Body	Instrument Cluster																																																											
C	2013	Spark	Body	Radio																																																											
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module										V																																																	
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module										V																																																	
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																											
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																	
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																									
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																									
C	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.0L LMT Engine Control Module										V																																															
C	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module										V																																															
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																									
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																									
C	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																									
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module										V																																															
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
C	2014	Spark	Powertrain	Fuel Injector Control Module																																																									
C	2014	Spark	Chassis	Electronic Brake Control Module																																																									
C	2014	Spark	Chassis	Electronic Brake Control Module																																																									
C	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
C	2014	Spark	Chassis	Power Steering Control Module																																																									
C	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2014	Spark	Body	Body Control Module																																																									
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2014	Spark	Body	Passenger Presence Module																																																									
C	2014	Spark	Body	Instrument Cluster																																																									
C	2014	Spark	Body	Radio																																																									
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																									
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2014	Spark	Body	Keyless Entry Control Module						V																																																			
C	2014	Spark EV	Powertrain	Engine Control Module																																																									
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																													V											
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																													V	V	V	V	V		V	V	V			V	V
C	2014	Spark EV	Powertrain	Drive Motor Control Module																																																								
C	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								
C	2014	Spark EV	Chassis	Electronic Brake Control Module																																																								
C	2014	Spark EV	Chassis	Parking Brake Control Module																																																								
C	2014	Spark EV	Chassis	Power Steering Control Module																																																								
C	2014	Spark EV	Body	Body Control Module																																																								
C	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
C	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Spark EV	Body	Passenger Presence Module																																																								
C	2014	Spark EV	Body	Instrument Cluster																																																								
C	2014	Spark EV	Body	Radio																																																								
C	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2014	Spark EV	Body	HVAC Control Module																																																									
C	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																									
C	2014	Spark EV	Body	Coolant Heater Control Module																																																									
C	2014	Spark EV	Body	Keyless Entry Control Module																																																									
C	2014	Spark EV	Body	Battery Charger Control Module																																																									
C	2014	Spark EV	Body	DC Charging Control Module																																																									
C	2014	Spark EV	Body	Battery Energy Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2015	Spark	Powertrain	0.8L LBF Engine Control Module										V																																																
C	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LA2 Engine Control Module										V																																																
C	2015	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																
C	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Engine Control Module										V																																																
C	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Spark	Chassis	Power Steering Control Module																																																										
C	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Spark	Body	Body Control Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Passenger Presence Module																																																										
C	2015	Spark	Body	Instrument Cluster																																																										
C	2015	Spark	Body	Instrument Cluster																																																										
C	2015	Spark	Body	Tire Pressure Indicator Module																																																										
C	2015	Spark	Body	Radio																																																										
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Spark	Body	Keyless Entry Control Module						V																																																				
C	2015	Spark EV	Powertrain	Engine Control Module																																																										
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																															V											
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																															V	V	V	V	V		V	V	V			V	V
C	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
C	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
C	2015	Spark EV	Chassis	Power Steering Control Module																																																										
C	2015	Spark EV	Body	Body Control Module																																																										
C	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark EV	Body	Passenger Presence Module																																																										
C	2015	Spark EV	Body	Instrument Cluster																																																										
C	2015	Spark EV	Body	Radio																																																										
C	2015	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2015	Spark EV	Body	Coolant Heater Control Module																																																										
C	2015	Spark EV	Body	Keyless Entry Control Module																																																										
C	2015	Spark EV	Body	Battery Charger Control Module																																																										
C	2015	Spark EV	Body	DC Charging Control Module																																																										
C	2015	Spark EV	Body	Battery Energy Control Module																																																										
C	2016	Spark	Powertrain	0.8L LBF Engine Control Module										V																																																
C	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
C	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.0L LA2 Engine Control Module										V																																																
C	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																										
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
C	2016	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																
C	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.0L LMT Engine Control Module										V																																																
C	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
C	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																										
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																										
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
C	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2016	Spark	Chassis	Electronic Brake Control Module																																																										
C	2016	Spark	Chassis	Electronic Brake Control Module																																																										
C	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2016	Spark	Chassis	Power Steering Control Module																																																										
C	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Spark	Body	Body Control Module																																			V																						
C	2016	Spark	Body	Body Control Module																																																									
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Spark	Body	Instrument Cluster																																																										
C	2016	Spark	Body	Instrument Cluster																																																										
C	2016	Spark	Body	Radio																																																										
C	2016	Spark	Body	Telematics Communication Interface Control Module																																																										
C	2016	Spark	Body	Keyless Entry Control Module						V																																																				
C	2016	Spark EV	Powertrain	Engine Control Module																																																										
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																														V											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																														V	V	V	V	V		V	V	V			V	V
C	2016	Spark EV	Powertrain	Drive Motor Control Module																																																										
C	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2016	Spark EV	Chassis	Electronic Brake Control Module																																																										
C	2016	Spark EV	Chassis	Parking Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2016	Spark EV	Chassis	Power Steering Control Module																																																										
C	2016	Spark EV	Body	Body Control Module																																																										
C	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Spark EV	Body	Passenger Presence Module																																																										
C	2016	Spark EV	Body	Instrument Cluster																																																										
C	2016	Spark EV	Body	Radio																																																										
C	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
C	2016	Spark EV	Body	HVAC Control Module																																																										
C	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2016	Spark EV	Body	Coolant Heater Control Module																																																										
C	2016	Spark EV	Body	Keyless Entry Control Module																																																										
C	2016	Spark EV	Body	Frontview Camera Module																																																										
C	2016	Spark EV	Body	Battery Charger Control Module																																																										
C	2016	Spark EV	Body	DC Charging Control Module																																																										
C	2016	Spark EV	Body	Battery Energy Control Module																																																										
D	2010	Spark	Powertrain	1.0L LCP Engine Control Module										V																																															
D	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2010	Spark	Powertrain	1.0L LMT Engine Control Module										V																																															
D	2010	Spark	Powertrain	1.2L LMU Engine Control Module										V																																															
D	2010	Spark	Powertrain	Transmission Control Module																																																										
D	2010	Spark	Chassis	Electronic Brake Control Module																																																										
D	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2010	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2010	Spark	Body	Passenger Presence Module																																																										
D	2010	Spark	Body	Instrument Cluster																																																										
D	2011	Spark	Powertrain	1.0L LCP Engine Control Module										V																																															
D	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module										V																																															
D	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module										V																																															
D	2011	Spark	Powertrain	Transmission Control Module																																																										
D	2011	Spark	Chassis	Electronic Brake Control Module																																																										
D	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2011	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2011	Spark	Body	Passenger Presence Module																																																										
D	2011	Spark	Body	Instrument Cluster																																																										
D	2012	Spark	Powertrain	1.0L LCP Engine Control Module										V																																															
D	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module										V																																															

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2012	Spark	Powertrain	1.19L LC5 Engine Control Module										V																																																
D	2012	Spark	Powertrain	1.2L L2E Engine Control Module										V																																																
D	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module										V																																																
D	2012	Spark	Powertrain	Transmission Control Module																																																										
D	2012	Spark	Chassis	Electronic Brake Control Module																																																										
D	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2012	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2012	Spark	Body	Passenger Presence Module																																																										
D	2012	Spark	Body	Instrument Cluster																																																										
D	2013	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																
D	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2013	Spark	Powertrain	1.0L LMT Engine Control Module										V																																																
D	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2013	Spark	Powertrain	1.19L LC5 Engine Control Module										V																																																
D	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																										
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
D	2013	Spark	Powertrain	1.2L L2E Engine Control Module										V																																																
D	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																										
D	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2013	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
D	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2013	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2013	Spark	Chassis	Electronic Brake Control Module																																																										
D	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2013	Spark	Chassis	Power Steering Control Module																																																										
D	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2013	Spark	Body	Body Control Module																																																										
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2013	Spark	Body	Passenger Presence Module																																																										
D	2013	Spark	Body	Instrument Cluster																																																										
D	2013	Spark	Body	Radio																																																										
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2014	Spark	Powertrain	0.8L LBF Engine Control Module										V																																																
D	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.0L LA2 Engine Control Module										V																																																
D	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																
D	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
D	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.0L LMT Engine Control Module										V																																																
D	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
D	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2014	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2014	Spark	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2014	Spark	Chassis	Power Steering Control Module																																																											
D	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2014	Spark	Body	Body Control Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Passenger Presence Module																																																											
D	2014	Spark	Body	Instrument Cluster																																																											
D	2014	Spark	Body	Radio																																																											
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark	Body	Keyless Entry Control Module						V																																																					
D	2014	Spark EV	Powertrain	Engine Control Module																																																											
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																													V														
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																													V	V	V	V	V		V	V	V			V	V
D	2014	Spark EV	Powertrain	Drive Motor Control Module																																																											
D	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
D	2014	Spark EV	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark EV	Chassis	Parking Brake Control Module																																																											
D	2014	Spark EV	Chassis	Power Steering Control Module																																																											
D	2014	Spark EV	Body	Body Control Module																																																											
D	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
D	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark EV	Body	Passenger Presence Module																																																											
D	2014	Spark EV	Body	Instrument Cluster																																																											
D	2014	Spark EV	Body	Radio																																																											
D	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark EV	Body	HVAC Control Module																																																											
D	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																											
D	2014	Spark EV	Body	Coolant Heater Control Module																																																											
D	2014	Spark EV	Body	Keyless Entry Control Module																																																											
D	2014	Spark EV	Body	Battery Charger Control Module																																																											
D	2014	Spark EV	Body	DC Charging Control Module																																																											
D	2014	Spark EV	Body	Battery Energy Control Module																																																											
D	2015	Spark	Powertrain	0.8L LBF Engine Control Module										V																																																
D	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LA2 Engine Control Module										V																																																
D	2015	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																
D	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module										V																																															
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																									
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module										V																																															
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																									
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																									
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																									
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																									
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module										V																																															
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
D	2015	Spark	Powertrain	Fuel Injector Control Module																																																									
D	2015	Spark	Chassis	Electronic Brake Control Module																																																									
D	2015	Spark	Chassis	Electronic Brake Control Module																																																									
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
D	2015	Spark	Chassis	Power Steering Control Module																																																									
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
D	2015	Spark	Body	Body Control Module																																																									
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2015	Spark	Body	Passenger Presence Module																																																									
D	2015	Spark	Body	Instrument Cluster																																																									
D	2015	Spark	Body	Instrument Cluster																																																									
D	2015	Spark	Body	Tire Pressure Indicator Module																																																									
D	2015	Spark	Body	Radio																																																									
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																									
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																									
D	2015	Spark	Body	Keyless Entry Control Module						V																																																			
D	2015	Spark EV	Powertrain	Engine Control Module																																																									
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																														V											
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																														V	V	V	V	V		V	V	V			V	V
D	2015	Spark EV	Powertrain	Drive Motor Control Module																																																									
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																									
D	2015	Spark EV	Chassis	Electronic Brake Control Module																																																									
D	2015	Spark EV	Chassis	Parking Brake Control Module																																																									
D	2015	Spark EV	Chassis	Power Steering Control Module																																																									
D	2015	Spark EV	Body	Body Control Module																																																									
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																									
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2015	Spark EV	Body	Passenger Presence Module																																																									
D	2015	Spark EV	Body	Instrument Cluster																																																									
D	2015	Spark EV	Body	Radio																																																									
D	2015	Spark EV	Body	HVAC Control Module																																																									
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																									
D	2015	Spark EV	Body	Coolant Heater Control Module																																																									
D	2015	Spark EV	Body	Keyless Entry Control Module																																																									
D	2015	Spark EV	Body	Battery Charger Control Module																																																									
D	2015	Spark EV	Body	DC Charging Control Module																																																									
D	2015	Spark EV	Body	Battery Energy Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2016	Spark	Powertrain	0.8L LBF Engine Control Module										V																																																
D	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.0L LA2 Engine Control Module										V																																																
D	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																
D	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2016	Spark	Powertrain	1.0L LMT Engine Control Module										V																																																
D	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
D	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																											
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																											
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																											
D	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																											
D	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																											
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																											
D	2016	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2016	Spark	Chassis	Electronic Brake Control Module																																																											
D	2016	Spark	Chassis	Electronic Brake Control Module																																																											
D	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2016	Spark	Chassis	Power Steering Control Module																																																											
D	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2016	Spark	Body	Body Control Module																																				V																						
D	2016	Spark	Body	Body Control Module																																																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2016	Spark	Body	Instrument Cluster																																																											
D	2016	Spark	Body	Instrument Cluster																																																											
D	2016	Spark	Body	Radio																																																											
D	2016	Spark	Body	Telematics Communication Interface Control Module																																																											
D	2016	Spark	Body	Keyless Entry Control Module						V																																																					
D	2016	Spark EV	Powertrain	Engine Control Module																																																												
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																															V												
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																														V	V	V	V	V		V	V	V			V	V
D	2016	Spark EV	Powertrain	Drive Motor Control Module																																																											
D	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
D	2016	Spark EV	Chassis	Electronic Brake Control Module																																																											
D	2016	Spark EV	Chassis	Parking Brake Control Module																																																											
D	2016	Spark EV	Chassis	Power Steering Control Module																																																											
D	2016	Spark EV	Body	Body Control Module																																																											
D	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
D	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2016	Spark EV	Body	Passenger Presence Module																																																											
D	2016	Spark EV	Body	Instrument Cluster																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2016	Spark EV	Body	Radio																																																										
D	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
D	2016	Spark EV	Body	HVAC Control Module																																																										
D	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
D	2016	Spark EV	Body	Coolant Heater Control Module																																																										
D	2016	Spark EV	Body	Keyless Entry Control Module																																																										
D	2016	Spark EV	Body	Frontview Camera Module																																																										
D	2016	Spark EV	Body	Battery Charger Control Module																																																										
D	2016	Spark EV	Body	DC Charging Control Module																																																										
D	2016	Spark EV	Body	Battery Energy Control Module																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Automatic Transmission																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Manual Transmission																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Transmission Control Module																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2010	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2010	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2010	Camaro	Chassis	Power Steering Control Module																																																										
F	2010	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2010	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2010	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2010	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2010	Camaro	Body	Passenger Presence Module																																																										
F	2010	Camaro	Body	Instrument Cluster																																																										
F	2010	Camaro	Body	Auxiliary Gage Module																																																										
F	2010	Camaro	Body	Radio																																																										
F	2010	Camaro	Body	Multimedia Player Interface Module																																																										
F	2010	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																										
F	2010	Camaro	Body	Mobile Telephone Control Module																																																										
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2010	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																										
F	2010	Camaro	Body	Front Seat Heating Control Module																																																										
F	2010	Camaro	Body	Folding Top Control Module																																																										
F	2010	Camaro	Body	Parking Assist Control Module																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Automatic Transmission																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Manual Transmission																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																										
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2011	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2011	Camaro	Chassis	Power Steering Control Module																																																										
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2011	Camaro	Body	Passenger Presence Module																																																										
F	2011	Camaro	Body	Instrument Cluster																																																										
F	2011	Camaro	Body	Head-Up Display Module																																																										
F	2011	Camaro	Body	Auxiliary Gage Module																																																										
F	2011	Camaro	Body	Headlamp Control Module																																																										
F	2011	Camaro	Body	Radio																																																										
F	2011	Camaro	Body	Multimedia Player Interface Module																																																										
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																										
F	2011	Camaro	Body	Mobile Telephone Control Module																																																										
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																										
F	2011	Camaro	Body	Front Seat Heating Control Module																																																										
F	2011	Camaro	Body	Folding Top Control Module																																																										
F	2011	Camaro	Body	Parking Assist Control Module																																																										
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																										
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																										
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																										
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module																																																										
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																										
F	2012	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2012	Camaro	Chassis	Power Steering Control Module																																																										
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2012	Camaro	Chassis	Suspension Control Module																																																										
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2012	Camaro	Body	Passenger Presence Module																																																										
F	2012	Camaro	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
F	2012	Camaro	Body	Head-Up Display Module																																																										
F	2012	Camaro	Body	Auxiliary Gage Module																																																										
F	2012	Camaro	Body	Headlamp Control Module																																																										
F	2012	Camaro	Body	Radio																																																										
F	2012	Camaro	Body	Multimedia Player Interface Module																																																										
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																										
F	2012	Camaro	Body	Mobile Telephone Control Module																																																										
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																										
F	2012	Camaro	Body	Front Seat Heating Control Module																																																										
F	2012	Camaro	Body	Folding Top Control Module																																																										
F	2012	Camaro	Body	Parking Assist Control Module																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow																																																										
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow																																																										
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow																																																										
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow																																																										
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																										
F	2013	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2013	Camaro	Chassis	Power Steering Control Module																																																										
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2013	Camaro	Chassis	Suspension Control Module																																																										
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2013	Camaro	Body	Passenger Presence Module																																																										
F	2013	Camaro	Body	Instrument Cluster																																																										
F	2013	Camaro	Body	Head-Up Display Module																																																										
F	2013	Camaro	Body	Auxiliary Gage Module																																																										
F	2013	Camaro	Body	Headlamp Control Module																																																										
F	2013	Camaro	Body	Radio																																																										
F	2013	Camaro	Body	Multimedia Player Interface Module																																																										
F	2013	Camaro	Body	Mobile Telephone Control Module																																																										
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
F	2013	Camaro	Body	HVAC Control Module																																																									
F	2013	Camaro	Body	Front Seat Heating Control Module																																																										
F	2013	Camaro	Body	Folding Top Control Module																																																										
F	2013	Camaro	Body	Parking Assist Control Module																																																										
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																										
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																										
F	2014	Camaro	Powertrain	Transmission Control Module																																																										
F	2014	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2014	Camaro	Chassis	Parking Brake Control Module																																																										
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2014	Camaro	Chassis	Power Steering Control Module																																																										
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2014	Camaro	Chassis	Suspension Control Module																																																										
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2014	Camaro	Body	Passenger Presence Module																																																										
F	2014	Camaro	Body	Instrument Cluster																																																										
F	2014	Camaro	Body	Head-Up Display Module																																																										
F	2014	Camaro	Body	Auxiliary Gage Module																																																										
F	2014	Camaro	Body	Headlamp Control Module																																																										
F	2014	Camaro	Body	Radio																																																										
F	2014	Camaro	Body	Mobile Telephone Control Module																																																										
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2014	Camaro	Body	HVAC Control Module																																																										
F	2014	Camaro	Body	Front Seat Heating Control Module																																																										
F	2014	Camaro	Body	Folding Top Control Module																																																										
F	2014	Camaro	Body	Parking Assist Control Module																																																										
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module																																																										
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2014	SS	Powertrain	Chassis Control Module																																																										
F	2014	SS	Chassis	Electronic Brake Control Module																																																										
F	2014	SS	Chassis	Parking Brake Control Module																																																										
F	2014	SS	Chassis	Power Steering Control Module																																																										
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2014	SS	Body	Body Control Module																																																										
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2014	SS	Body	Passenger Presence Module																																																										
F	2014	SS	Body	Instrument Cluster																																																										
F	2014	SS	Body	Head-Up Display Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
F	2014	SS	Body	Radio Control																																																									
F	2014	SS	Body	HVAC Control																																																									
F	2014	SS	Body	Headlamp Control Module																																																									
F	2014	SS	Body	Trailer Interface Control Module																																																									
F	2014	SS	Body	Radio																																																									
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9																																																									
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10																																																									
F	2014	SS	Body	HVAC Control Module																																																									
F	2014	SS	Body	Seat Memory Control Module - Driver																																																									
F	2014	SS	Body	Keyless Entry Control Module																																																									
F	2014	SS	Body	Right Side Object Detection Control Module																																																									
F	2014	SS	Body	Left Side Object Detection Control Module																																																									
F	2014	SS	Body	Parking Assist Control Module																																																									
F	2014	SS	Body	Frontview Camera Module																																																									
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																									
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																									
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																									
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																									
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																									
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																									
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																									
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																									
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																									
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																									
F	2015	Camaro	Powertrain	Transmission Control Module																																																									
F	2015	Camaro	Chassis	Electronic Brake Control Module																																																									
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																									
F	2015	Camaro	Chassis	Power Steering Control Module																																																									
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																									
F	2015	Camaro	Chassis	Suspension Control Module																																																									
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
F	2015	Camaro	Body	Passenger Presence Module																																																									
F	2015	Camaro	Body	Instrument Cluster																																																									
F	2015	Camaro	Body	Head-Up Display Module																																																									
F	2015	Camaro	Body	Auxiliary Gage Module																																																									
F	2015	Camaro	Body	Headlamp Control Module																																																									
F	2015	Camaro	Body	Radio																																																									
F	2015	Camaro	Body	Mobile Telephone Control Module																																																									
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6																																																									
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																									
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																									
F	2015	Camaro	Body	HVAC Control Module																																																									
F	2015	Camaro	Body	Front Seat Heating Control Module																																																									
F	2015	Camaro	Body	Folding Top Control Module																																																									
F	2015	Camaro	Body	Parking Assist Control Module																																																									
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																									
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2015	SS	Powertrain	Fuel Injector Control Module																																																											
F	2015	SS	Powertrain	Chassis Control Module																																																										
F	2015	SS	Chassis	Electronic Brake Control Module																																																										
F	2015	SS	Chassis	Parking Brake Control Module																																																										
F	2015	SS	Chassis	Power Steering Control Module																																																										
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2015	SS	Chassis	Suspension Control Module																																																										
F	2015	SS	Body	Body Control Module																																																										
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2015	SS	Body	Passenger Presence Module																																																										
F	2015	SS	Body	Instrument Cluster																																																										
F	2015	SS	Body	Head-Up Display Module																																																										
F	2015	SS	Body	Radio Control																																																										
F	2015	SS	Body	HVAC Control																																																										
F	2015	SS	Body	Headlamp Control Module																																																										
F	2015	SS	Body	Trailer Interface Control Module																																																										
F	2015	SS	Body	Radio																																																										
F	2015	SS	Body	Telematics Communication Interface Control Module																																																										
F	2015	SS	Body	HVAC Control Module																																																										
F	2015	SS	Body	Seat Memory Control Module - Driver																																																										
F	2015	SS	Body	Keyless Entry Control Module																																																										
F	2015	SS	Body	Right Side Object Detection Control Module																																																										
F	2015	SS	Body	Left Side Object Detection Control Module																																																										
F	2015	SS	Body	Parking Assist Control Module																																																										
F	2015	SS	Body	Frontview Camera Module																																																										
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																															V																												
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																															V																												
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																										
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																										
F	2016	Camaro	Powertrain	Transmission Control Module																																																										
F	2016	Camaro	Chassis	Electronic Brake Control Module																																	V	V																								
F	2016	Camaro	Chassis	Parking Brake Control Module																																																										
F	2016	Camaro	Chassis	Power Steering Control Module																																																										
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2016	Camaro	Chassis	Suspension Control Module																																																										
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2016	Camaro	Body	Serial Data Gateway Module																																																										
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2016	Camaro	Body	Passenger Presence Module																																																										
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																										
F	2016	Camaro	Body	Head-Up Display Module																																																										
F	2016	Camaro	Body	Auxiliary Gage Module																																																										
F	2016	Camaro	Body	Radio Controls																																																										
F	2016	Camaro	Body	HVAC Controls																																																										
F	2016	Camaro	Body	Vehicle Performance Data Recorder																																																										
F	2016	Camaro	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
F	2016	Camaro	Body	Amplifier																																																									
F	2016	Camaro	Body	Media Disc Player																																																									
F	2016	Camaro	Body	Human Machine Interface Control Module																																																									
F	2016	Camaro	Body	Navigation Control Module																																																									
F	2016	Camaro	Body	Mobile Telephone Control Module																																																									
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																									
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																									
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)																																																									
F	2016	Camaro	Body	Seat Memory Control Module - Driver																																																									
F	2016	Camaro	Body	Folding Top Control Module																																																									
F	2016	Camaro	Body	Keyless Entry Control Module																																																									
F	2016	Camaro	Body	Right Side Object Detection Control Module																																																									
F	2016	Camaro	Body	Left Side Object Detection Control Module																																																									
F	2016	Camaro	Body	Parking Assist Control Module																																																									
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																									
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																									
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																									
F	2016	SS	Powertrain	Fuel Injector Control Module																																																									
F	2016	SS	Chassis	Electronic Brake Control Module																																																									
F	2016	SS	Chassis	Parking Brake Control Module																																																									
F	2016	SS	Chassis	Power Steering Control Module																																																									
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module																																																									
F	2016	SS	Chassis	Suspension Control Module																																																									
F	2016	SS	Body	Body Control Module																																																									
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
F	2016	SS	Body	Passenger Presence Module																																																									
F	2016	SS	Body	Instrument Cluster																																																									
F	2016	SS	Body	Head-Up Display Module																																																									
F	2016	SS	Body	Radio Control																																																									
F	2016	SS	Body	HVAC Control																																																									
F	2016	SS	Body	Trailer Interface Control Module																																																									
F	2016	SS	Body	Radio																																																									
F	2016	SS	Body	Telematics Communication Interface Control Module																																																									
F	2016	SS	Body	HVAC Control Module																																																									
F	2016	SS	Body	Seat Memory Control Module - Driver	V																																																								
F	2016	SS	Body	Keyless Entry Control Module																																																									
F	2016	SS	Body	Right Side Object Detection Control Module																																																									
F	2016	SS	Body	Left Side Object Detection Control Module																																																									
F	2016	SS	Body	Parking Assist Control Module																																																									
F	2016	SS	Body	Frontview Camera Module																																																									
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																									
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																									
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
G	2016	Malibu	Powertrain	Fuel Injector Control Module																																	V	V																							
G	2016	Malibu	Powertrain	Chassis Control Module																																																									
G	2016	Malibu	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2016	Malibu	Chassis	Parking Brake Control Module																																																											
G	2016	Malibu	Chassis	Power Steering Control Module																																																												
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																												
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2016	Malibu	Body	Passenger Presence Module																																																												
G	2016	Malibu	Body	Instrument Cluster																																																												
G	2016	Malibu	Body	Headlamp Control Module																																																												
G	2016	Malibu	Body	Radio																																																												
G	2016	Malibu	Body	Digital Radio Receiver Control Module																																																												
G	2016	Malibu	Body	Multimedia Player Interface Module																																																												
G	2016	Malibu	Body	Mobile Telephone Control Module																																																												
G	2016	Malibu	Body	Telematics Communication Interface Control Module																																																												
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																												
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																												
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																												
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																												
G	2016	Malibu	Body	Seat Memory Control Module																																																												
G	2016	Malibu	Body	Front Seat Heating Control Module																																																												
G	2016	Malibu	Body	Rear Seat Heating Control Module																																																												
G	2016	Malibu	Body	Keyless Entry Control Module																																																												
G	2016	Malibu	Body	Left Side Object Detection Control Module																																																												
G	2016	Malibu	Body	Parking Assist Control Module																																																												
G	2016	Malibu	Body	Frontview Camera Module																																																												
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																																	
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																																	
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module										V																																																	
H	2010	Sail	Powertrain	Transmission Control Module																																																												
H	2010	Sail	Chassis	Electronic Brake Control Module																																																												
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission										V																																																	
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission										V																																																	
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module										V																																																	
H	2011	Sail	Powertrain	Transmission Control Module																																																												
H	2011	Sail	Chassis	Electronic Brake Control Module																																																												
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission										V																																																	
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission										V																																																	
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission										V																																																	
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission										V																																																	
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																																	
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																																	
H	2012	Sail	Powertrain	Transmission Control Module																																																												
H	2012	Sail	Chassis	Electronic Brake Control Module																																																												
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																																	
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																																	
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																																
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																																
H	2013	Sail	Powertrain	Transmission Control Module																																																											
H	2013	Sail	Chassis	Electronic Brake Control Module																																																											
H	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																																
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																																
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																																
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																																
H	2014	Sail	Powertrain	Transmission Control Module																																																											
H	2014	Sail	Chassis	Electronic Brake Control Module																																																											
H	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																											
H	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																											
H	2015	Sail	Chassis	Electronic Brake Control Module																																																											
H	2015	Sail	Chassis	Power Steering Control Module																																																											
H	2015	Sail	Body	Body Control Module																																																										
H	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2015	Sail	Body	Radio/HVAC Control																																																											
H	2015	Sail	Body	HVAC Control Module																																																											
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																											
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																											
H	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																											
H	2016	Sail	Chassis	Electronic Brake Control Module																																																											
H	2016	Sail	Chassis	Power Steering Control Module																																																											
H	2016	Sail	Body	Body Control Module																																																										
H	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2016	Sail	Body	Radio/HVAC Control																																																											
H	2016	Sail	Body	Radio																																																											
H	2016	Sail	Body	HVAC Control Module																																																											
J	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																																	
J	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module										V																																																	
J	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module										V																																																	
J	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																																	
J	2004	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																											
J	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																											
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																											
J	2004	Optra	Body	Remote Function Actuation																																																											
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																											
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module											V																																																
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel																																																											
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel Transmission Control Module											V																																																
J	2004	Cavalier	Chassis	Anti-lock Brake System																																																											
J	2004	Cavalier	Body	Body Control Module																																																											
J	2004	Cavalier	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2004	Cavalier	Body	Instrument Panel Cluster																																																										
J	2004	Cavalier	Body	Radio																	V	V																																							
J	2004	Cavalier	Body	Supplemental Inflatable Restraint												V	V																																												
J	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																															
J	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module										V																																															
J	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module										V																																															
J	2005	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
J	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
J	2005	Optra	Body	Remote Function Actuation																																																										
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module											V																																															
J	2005	Cavalier	Chassis	Anti-lock Brake System																																																										
J	2005	Cavalier	Body	Body Control Module																																																										
J	2005	Cavalier	Body	Digital Radio Receiver																																																										
J	2005	Cavalier	Body	Instrument Panel Cluster																																																										
J	2005	Cavalier	Body	Radio																	V	V																																								
J	2005	Cavalier	Body	Supplemental Inflatable Restraint																																																										
J	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																															
J	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module										V																																															
J	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module										V																																															
J	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																															
J	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
J	2006	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
J	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2006	ALL	Body	Remote Function Actuation																																																										
J	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
J	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																															
J	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module										V																																															
J	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																															
J	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
J	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																															
J	2007	ALL	Powertrain	4 Speed Automatic																																																										
J	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																										
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																										
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																										
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																										
J	2007	ALL	Chassis	Tire Pressure Monitor																																																										
J	2007	ALL	Body	Remote Function Actuation																																																										
J	2007	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
J	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module										V																																																
J	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																																
J	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																																
J	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																																
J	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module										V																																																
J	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																										
J	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2008	ALL	Chassis	Tire Pressure Monitor																																																										
J	2008	ALL	Body	Remote Function Actuation																																																										
J	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
J	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
J	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module										V																																																
J	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																																
J	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																																
J	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																																
J	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																										
J	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2009	ALL	Chassis	Tire Pressure Monitor																																																										
J	2009	ALL	Body	Remote Function Actuation																																																										
J	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission										V																																																
J	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																										
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																										
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																										
J	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																										
J	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																										
J	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																										
J	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																										
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																										
J	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																										
J	2010	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2010	Cruze	Body	Body Control Module																																																										
J	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2010	Cruze	Body	Passenger Presence Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2010	Cruze	Body	Instrument Cluster																																																										
J	2010	Cruze	Body	Trailer Interface Control Module																																																											
J	2010	Cruze	Body	Radio																																																										
J	2010	Cruze	Body	Multimedia Player Interface Module																																																										
J	2010	Cruze	Body	Mobile Telephone Control Module																																																										
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
J	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
J	2010	Cruze	Body	Keyless Entry Control Module																																																										
J	2010	Cruze	Body	Parking Assist Control Module																																																										
J	2010	Cruze	Body	Steering Column Lock Control Module																																																										
J	2010	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2010	Other	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
J	2010	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																															
J	2010	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																															
J	2010	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
J	2010	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2010	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2010	Other	Powertrain	Transmission Control Module 5 Speed																																																										
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2010	Other	Chassis	Tire Pressure Monitor																																																										
J	2010	Other	Body	Remote Function Actuation																																																										
J	2010	Other	Body	Supplemental Inflatable Restraint																																																										
J	2010	Other	Body	Supplemental Inflatable Restraint																																																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																										
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission										V																																															
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission										V																																															
J	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																										
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																										
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																										
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																										
J	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																										
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission										V																																															
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission										V																																															
J	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																										
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																										
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																										
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																										
J	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																										
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission										V																																															
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																															
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2011	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2011	Cruze	Body	Body Control Module																																																										
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2011	Cruze	Body	Passenger Presence Module																																																										
J	2011	Cruze	Body	Instrument Cluster																																																										
J	2011	Cruze	Body	Trailer Interface Control Module																																																										
J	2011	Cruze	Body	Radio																																																										
J	2011	Cruze	Body	Multimedia Player Interface Module																																																										
J	2011	Cruze	Body	Mobile Telephone Control Module																																																										
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
J	2011	Cruze	Body	Keyless Entry Control Module																																																										
J	2011	Cruze	Body	Parking Assist Control Module																																																										
J	2011	Cruze	Body	Steering Column Lock Control Module																																																										
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																															
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																															
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2011	Other	Powertrain	Transmission Control Module 5 Speed																																																										
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2011	Other	Chassis	Tire Pressure Monitor																																																										
J	2011	Other	Body	Remote Function Actuation																																																										
J	2011	Other	Body	Supplemental Inflatable Restraint																																																										
J	2011	Other	Body	Supplemental Inflatable Restraint																																																										
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2012	Aveo	Powertrain	Fuel Pump Control Module																																																										
J	2012	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2012	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2012	Aveo	Chassis	Electric Power Steering Control Module																																																										
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2012	Aveo	Body	Body Control Module Hatchback																																																										
J	2012	Aveo	Body	Body Control Module Sedan																																																										
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2012	Aveo	Body	Passenger Presence Module																																																										
J	2012	Aveo	Body	Instrument Cluster																																																										
J	2012	Aveo	Body	Radio																																																										
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2012	Aveo	Body	Front Seat Heating Control Module																																																										
J	2012	Aveo	Body	Parking Assist Control Module																																																										
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																										
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																										
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2012	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																										
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2012	Cobalt	Body	Body Control Module																																																										
J	2012	Cobalt	Body	Passenger Presence Module																																																										
J	2012	Cobalt	Body	Instrument Cluster																																																										
J	2012	Cobalt	Body	Radio																																																										
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
J	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																										
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2012	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2012	Cobalt	Body	Parking Assist Control Module																																																										
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																										
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission										V																																																
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission										V																																																
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																										
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission										V																																																
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission										V																																																
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																																
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																																
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																										
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																										
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission										V																																																
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission										V																																																
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																										
J	2012	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2012	Cruze	Body	Body Control Module Hatchback																																																										
J	2012	Cruze	Body	Body Control Module Sedan																																																										
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2012	Cruze	Body	Passenger Presence Module																																																										
J	2012	Cruze	Body	Instrument Cluster																																																										
J	2012	Cruze	Body	Trailer Interface Control Module																																																										
J	2012	Cruze	Body	Radio																																																										
J	2012	Cruze	Body	Multimedia Player Interface Module																																																										
J	2012	Cruze	Body	Mobile Telephone Control Module																																																										
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
J	2012	Cruze	Body	Keyless Entry Control Module																																																									
J	2012	Cruze	Body	Parking Assist Control Module																																																									
J	2012	Cruze	Body	Steering Column Lock Control Module																																																									
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																														
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																														
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																									
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																									
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																									
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																									
J	2012	Sonic (First Gen)	Body	Remote Function Actuation																																																									
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																									
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																									
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module																																																									
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																									
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																									
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module Chassis Expansion CAN BUS																																																								
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module High Speed CAN Bus																																																								
J	2012	Sonic (Second Gen)	Body	Body Control Module Hatchback																																				V																			
J	2012	Sonic (Second Gen)	Body	Body Control Module Sedan																																				V																			
J	2012	Sonic (Second Gen)	Body	Passenger Presence Module																																																								
J	2012	Sonic (Second Gen)	Body	Instrument Cluster																																																								
J	2012	Sonic (Second Gen)	Body	Radio																																																								
J	2012	Sonic (Second Gen)	Body	Telematic Vehicle Localization and Immobilization Control Module																																																								
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																								
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																								
J	2012	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																								
J	2012	Sonic (Second Gen)	Body	Parking Assist Control Module																																																								
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
J	2013	Aveo	Powertrain	Fuel Pump Control Module																																																								
J	2013	Aveo	Powertrain	Fuel Injector Control Module																																																								
J	2013	Aveo	Chassis	Electronic Brake Control Module																																																								
J	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Aveo	Chassis	Electric Power Steering Control Module																																																								
J	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2013	Aveo	Body	Body Control Module Hatchback																																																								
J	2013	Aveo	Body	Body Control Module Sedan																																																								
J	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2013	Aveo	Body	Passenger Presence Module																																																								
J	2013	Aveo	Body	Instrument Cluster																																																								
J	2013	Aveo	Body	Radio																																																								
J	2013	Aveo	Body	Telematics Communication Interface Control Module																																																								
J	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
J	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								
J	2013	Aveo	Body	Front Seat Heating Control Module																																																								
J	2013	Aveo	Body	Parking Assist Control Module																																																								
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2013	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Cobalt	Body	Body Control Module																																																										
J	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Cobalt	Body	Instrument Cluster																																																										
J	2013	Cobalt	Body	Radio																																																									
J	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																										
J	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2013	Cobalt	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission										V																																															
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission										V																																															
J	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission										V																																															
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission										V																																															
J	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																															
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																															
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission										V																																															
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																															
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2013	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Cruze	Body	Body Control Module Hatchback																																																										
J	2013	Cruze	Body	Body Control Module Sedan																																																										
J	2013	Cruze	Body	Body Control Module Station Wagon																																																										
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Cruze	Body	Passenger Presence Module																																																										
J	2013	Cruze	Body	Instrument Cluster																																																										
J	2013	Cruze	Body	Trailer Interface Control Module																																																										
J	2013	Cruze	Body	Radio																																																										
J	2013	Cruze	Body	Digital Radio Receiver Control Module																																																										
J	2013	Cruze	Body	Multimedia Player Interface Module																																																										
J	2013	Cruze	Body	Mobile Telephone Control Module																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
J	2013	Cruze	Body	Front Seat Heating Control Module																																																										
J	2013	Cruze	Body	Keyless Entry Control Module																																																										
J	2013	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Body	Steering Column Lock Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																															
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																															
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																									
J	2013	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																									
J	2013	Sonic (First Gen)	Body	Remote Function Actuation																																																									
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																									
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Transmission Control Module																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																									
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																									
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Fuel Pump Control Module																																																									
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																									
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																									
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Fuel Pump Control Module																																																									
J	2013	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																									
J	2013	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2013	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2013	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																									
J	2013	Sonic (Second Gen)	Body	Body Control Module Sedan																																																									
J	2013	Sonic (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2013	Sonic (Second Gen)	Body	Passenger Presence Module																																																									
J	2013	Sonic (Second Gen)	Body	Instrument Cluster																																																									
J	2013	Sonic (Second Gen)	Body	Radio																																																									
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																									
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																										
J	2013	Sonic (Second Gen)	Body	Parking Assist Control Module																																																										
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2013	Spin	Chassis	Electronic Brake Control Module																																																										
J	2013	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Spin	Body	Body Control Module																																																										
J	2013	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Spin	Body	Instrument Cluster																																																										
J	2013	Spin	Body	Radio																																																										
J	2013	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Spin	Body	Parking Assist Control Module																																																										
J	2014	Aveo	Powertrain	1.2L LMU Engine Control Module										V																																															
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L95 Engine Control Module										V																																															
J	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module										V																																															

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module										V																																																
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	Chassis Control Module																																																										
J	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Aveo	Chassis	Power Steering Control Module																																																										
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Aveo	Body	Body Control Module Hatchback																																																										
J	2014	Aveo	Body	Body Control Module Sedan																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Instrument Cluster																																																										
J	2014	Aveo	Body	Radio																																																										
J	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Aveo	Body	Front Seat Heating Control Module																																																										
J	2014	Aveo	Body	Keyless Entry Control Module						V																																																			
J	2014	Aveo	Body	Parking Assist Control Module																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2014	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Cobalt	Body	Body Control Module																																																										
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Cobalt	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2014	Cobalt	Body	Radio																																																									
J	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									
J	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
J	2014	Cobalt	Body	Front Seat Heating Control Module																																																									
J	2014	Cobalt	Body	Parking Assist Control Module																																																									
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission										V																																															
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission										V																																															
J	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission										V																																															
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission										V																																															
J	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission										V																																															
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission										V																																															
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																															
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																															
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission										V																																															
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																															
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module										V																																															
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																										
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																										
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																										
J	2014	Cruze	Powertrain	Fuel Injector Control Module																																																										
J	2014	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Cruze	Chassis	Power Steering Control Module																																																										
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Cruze	Body	Body Control Module Hatchback																																																										
J	2014	Cruze	Body	Body Control Module Sedan																																																										
J	2014	Cruze	Body	Body Control Module Station Wagon																																																										
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Cruze	Body	Passenger Presence Module																																																										
J	2014	Cruze	Body	Instrument Cluster																																																										
J	2014	Cruze	Body	Trailer Interface Control Module																																																										
J	2014	Cruze	Body	Radio																																																										
J	2014	Cruze	Body	Digital Radio Receiver Control Module																																																										
J	2014	Cruze	Body	Multimedia Player Interface Module																																																										
J	2014	Cruze	Body	Mobile Telephone Control Module																																																										
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
J	2014	Cruze	Body	Front Seat Heating Control Module																																																										
J	2014	Cruze	Body	Keyless Entry Control Module																																																										
J	2014	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2014	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2014	Cruze	Body	Parking Assist Control Module																																																										
J	2014	Cruze	Body	Steering Column Lock Control Module																																																										
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2014	Sonic	Powertrain	1.4L LDD Chassis Control Module																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Chassis Control Module																																																										
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Chassis Control Module																																																										
J	2014	Sonic	Powertrain	Fuel Injector Control Module																																																										
J	2014	Sonic	Chassis	Electronic Brake Control Module																																																										
J	2014	Sonic	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Sonic	Chassis	Power Steering Control Module																																																										
J	2014	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Sonic	Body	Body Control Module Hatchback																																																										
J	2014	Sonic	Body	Body Control Module Sedan																																																										
J	2014	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Sonic	Body	Passenger Presence Module																																																										
J	2014	Sonic	Body	Instrument Cluster																																																										
J	2014	Sonic	Body	Radio																																																										
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Sonic	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Sonic	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Sonic	Body	Front Seat Heating Control Module																																																										
J	2014	Sonic	Body	Parking Assist Control Module																																																										
J	2014	Sonic	Body	Frontview Camera Module																																																										
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.5L L2B Transmission Control Module																																																										
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2014	Spin	Chassis	Electronic Brake Control Module																																																										
J	2014	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Spin	Body	Body Control Module																																																									
J	2014	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Spin	Body	Instrument Cluster																																																									
J	2014	Spin	Body	Radio																																																									
J	2014	Spin	Body	HVAC Control Module Heater Only (C41)																																																									
J	2014	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2014	Spin	Body	HVAC Control Module Single Zone (C60)																																																									
J	2014	Spin	Body	Parking Assist Control Module																																																									
J	2015	Aveo	Powertrain	1.2L LMU Engine Control Module										V																																															
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L L95 Engine Control Module										V																																															
J	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module										V																																															
J	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module										V																																																
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2015	Aveo	Powertrain	Chassis Control Module																																																										
J	2015	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2015	Aveo	Chassis	Power Steering Control Module																																																										
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Aveo	Body	Body Control Module Hatchback																																																										
J	2015	Aveo	Body	Body Control Module Sedan																																																										
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Aveo	Body	Instrument Cluster																																																										
J	2015	Aveo	Body	Radio																																																										
J	2015	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Aveo	Body	Front Seat Heating Control Module																																																										
J	2015	Aveo	Body	Keyless Entry Control Module						V																																																			
J	2015	Aveo	Body	Parking Assist Control Module																																																										
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2015	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Cobalt	Body	Body Control Module																																																										
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Cobalt	Body	Instrument Cluster																																																										
J	2015	Cobalt	Body	Radio																																																										
J	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																										
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2015	Cobalt	Body	Parking Assist Control Module																																																										
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission										V																																															
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission										V																																															
J	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission										V																																															
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission										V																																															
J	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission										V																																															
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission										V																																															
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																															
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																															
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission										V																																															
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																															
J	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module										V																																															
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																									
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																									
J	2015	Cruze	Powertrain	Fuel Injector Control Module																																																									
J	2015	Cruze	Chassis	Electronic Brake Control Module																																																									
J	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2015	Cruze	Chassis	Power Steering Control Module																																																									
J	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2015	Cruze	Body	Body Control Module Hatchback																																																									
J	2015	Cruze	Body	Body Control Module Sedan																																																									
J	2015	Cruze	Body	Body Control Module Station Wagon																																																									
J	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2015	Cruze	Body	Passenger Presence Module																																																									
J	2015	Cruze	Body	Instrument Cluster																																																									
J	2015	Cruze	Body	Trailer Interface Control Module																																																									
J	2015	Cruze	Body	Radio																																																									
J	2015	Cruze	Body	Digital Radio Receiver Control Module																																																									
J	2015	Cruze	Body	Multimedia Player Interface Module																																																									
J	2015	Cruze	Body	Mobile Telephone Control Module																																																									
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																									
J	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																									
J	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																									
J	2015	Cruze	Body	Front Seat Heating Control Module																																																									
J	2015	Cruze	Body	Keyless Entry Control Module																																																									
J	2015	Cruze	Body	Right Side Object Detection Control Module																																																									
J	2015	Cruze	Body	Left Side Object Detection Control Module																																																									
J	2015	Cruze	Body	Parking Assist Control Module																																																									
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																									
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2015	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	1.6L LED Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2015	Sonic	Powertrain	Chassis Control Module																																																											
J	2015	Sonic	Powertrain	Fuel Injector Control Module																																																											
J	2015	Sonic	Chassis	Electronic Brake Control Module																																																											
J	2015	Sonic	Chassis	Power Steering Control Module																																																											
J	2015	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2015	Sonic	Body	Body Control Module Hatchback																																																											
J	2015	Sonic	Body	Body Control Module Sedan																																																											
J	2015	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2015	Sonic	Body	Passenger Presence Module																																																											
J	2015	Sonic	Body	Instrument Cluster																																																											
J	2015	Sonic	Body	Radio																																																											
J	2015	Sonic	Body	Telematics Communication Interface Control Module																																																											
J	2015	Sonic	Body	HVAC Control Module Heater Only (C41)																																																											
J	2015	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2015	Sonic	Body	HVAC Control Module Single Zone (C60)																																																											
J	2015	Sonic	Body	Front Seat Heating Control Module																																																											
J	2015	Sonic	Body	Parking Assist Control Module																																																											
J	2015	Sonic	Body	Frontview Camera Module																																																											
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																											
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.5L L2B Transmission Control Module																																																											
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2015	Spin	Chassis	Electronic Brake Control Module																																																											
J	2015	Spin	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2015	Spin	Body	Body Control Module																																																										
J	2015	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2015	Spin	Body	Instrument Cluster																																																											
J	2015	Spin	Body	Radio																																																										
J	2015	Spin	Body	Telematics Communication Interface Control Module																																																											
J	2015	Spin	Body	HVAC Control Module Heater Only (C41)																																																											
J	2015	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2015	Spin	Body	HVAC Control Module Single Zone (C60)																																																											
J	2015	Spin	Body	Front Seat Heating Control Module																																																											
J	2015	Spin	Body	Parking Assist Control Module																																																											
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.4L L95 Engine Control Module										V																																																
J	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																											
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module										V																																																	
J	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																											
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																											
J	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module										V																																																
J	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2016	Aveo	Powertrain	Chassis Control Module																																																											
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
J	2016	Aveo	Chassis	Power Steering Control Module																																																											
J	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Aveo	Body	Body Control Module Hatchback																																																											
J	2016	Aveo	Body	Body Control Module Sedan																																																											
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Aveo	Body	Instrument Cluster																																																											
J	2016	Aveo	Body	Radio																																																											
J	2016	Aveo	Body	Telematics Communication Interface Control Module																																																											
J	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
J	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Aveo	Body	Front Seat Heating Control Module																																																											
J	2016	Aveo	Body	Parking Assist Control Module																																																											
J	2016	Aveo	Body	Keyless Entry Control Module						V																																																					
J	2016	Aveo	Body	Frontview Camera Module																																																												
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2016	Cobalt	Chassis	Electronic Brake Control Module																																																											
J	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Cobalt	Body	Body Control Module																																																											
J	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Cobalt	Body	Instrument Cluster																																																											
J	2016	Cobalt	Body	Radio Other																																																											
J	2016	Cobalt	Body	Radio (IOB)																																																											
J	2016	Cobalt	Body	Radio (UF7)																																																											
J	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											
J	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Cobalt	Body	Front Seat Heating Control Module																																																											
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																												
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
J	2016	Cruze	Powertrain	Fuel Injector Control Module																																																												
J	2016	Cruze	Powertrain	Chassis Control Module																																																												
J	2016	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2016	Cruze	Chassis	Power Steering Control Module																																																												
J	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Cruze	Body	Body Control Module Hatchback																																																												
J	2016	Cruze	Body	Body Control Module Sedan																																																												
J	2016	Cruze	Body	Body Control Module Station Wagon																																																												
J	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Cruze	Body	Passenger Presence Module																																																												
J	2016	Cruze	Body	Instrument Cluster																																																												
J	2016	Cruze	Body	Trailer Interface Control Module																																																												
J	2016	Cruze	Body	Radio Other																																																											
J	2016	Cruze	Body	Radio (UF7)																																																											
J	2016	Cruze	Body	Multimedia Player Interface Module																																																											
J	2016	Cruze	Body	Mobile Telephone Control Module																																																											
J	2016	Cruze	Body	Telematics Communication Interface Control Module																																																											
J	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
J	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																											
J	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																											
J	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																											
J	2016	Cruze	Body	Front Seat Heating Control Module																																																											
J	2016	Cruze	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2016	Cruze	Body	Right Side Object Detection Control Module																																																											
J	2016	Cruze	Body	Left Side Object Detection Control Module																																																											
J	2016	Cruze	Body	Parking Assist Control Module																																																											
J	2016	Cruze	Body	Steering Column Lock Control Module																																																											
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																											
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module																																																											
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																											
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																											
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2016	Sonic	Powertrain	Chassis Control Module																																																											
J	2016	Sonic	Powertrain	Fuel Injector Control Module																																																											
J	2016	Sonic	Chassis	Electronic Brake Control Module																																																											
J	2016	Sonic	Chassis	Power Steering Control Module																																																											
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Sonic	Body	Body Control Module Hatchback																																																											
J	2016	Sonic	Body	Body Control Module Sedan																																																											
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Sonic	Body	Passenger Presence Module																																																											
J	2016	Sonic	Body	Instrument Cluster																																																											
J	2016	Sonic	Body	Radio Other																																																										
J	2016	Sonic	Body	Radio (UF7)																																																											
J	2016	Sonic	Body	Radio (UH7)																																																											
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7																																																											
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Sonic	Body	Front Seat Heating Control Module																																																											
J	2016	Sonic	Body	Parking Assist Control Module																																																											
J	2016	Sonic	Body	Frontview Camera Module																																																											
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module																																																											
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2016	Spin	Chassis	Electronic Brake Control Module																																																											
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Spin	Body	Body Control Module																																																										
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Spin	Body	Instrument Cluster																																																											
J	2016	Spin	Body	Radio																																																										
J	2016	Spin	Body	Telematics Communication Interface Control Module																																																											
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)																																																											
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Spin	Body	Front Seat Heating Control Module																																																											
J	2016	Spin	Body	Parking Assist Control Module																																																											
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																											
K	2006	ALL	Powertrain	Transmission Control Module																																																											
K	2006	ALL	Chassis	Electronic Brake Control Module																																																											
K	2006	ALL	Body	Remote Function Actuation																																																											
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																											
K	2007	ALL	Powertrain	Transmission Control Module																																																											
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module																																																											
K	2007	ALL	Chassis	Teves Electronic Brake Control Module																																																											
K	2007	ALL	Body	Remote Function Actuation																																																											
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																											
K	2008	ALL	Powertrain	Transmission Control Module																																																											
K	2008	ALL	Chassis	Electronic Brake Control Module																																																											
K	2008	ALL	Body	Remote Function Actuation																																																											
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																											
K	2009	ALL	Powertrain	Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2009	ALL	Chassis	Electronic Brake Control Module																																																									
K	2009	ALL	Body	Remote Function Actuation																																																									
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2010	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																									
K	2010	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																									
K	2010	ALL	Powertrain	Transmission Control Module																																																									
K	2010	ALL	Chassis	Electronic Brake Control Module																																																									
K	2010	ALL	Body	Remote Function Actuation																																																									
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2011	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																									
K	2011	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																									
K	2011	ALL	Powertrain	Transmission Control Module																																																									
K	2011	ALL	Chassis	Electronic Brake Control Module																																																									
K	2011	ALL	Body	Remote Function Actuation																																																									
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2012	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																									
K	2012	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																									
K	2012	ALL	Powertrain	Transmission Control Module																																																									
K	2012	ALL	Chassis	Electronic Brake Control Module																																																									
K	2012	ALL	Body	Remote Function Actuation																																																									
K	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2013	Onix	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																									
K	2013	Onix	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																									
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																									
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																									
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																									
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																									
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																									
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																									
K	2013	Onix	Powertrain	Transmission Control Module																																																									
K	2013	Onix	Powertrain	Transmission Control Module																																																									
K	2013	Onix	Chassis	Electronic Brake Control Module																																																									
K	2013	Onix	Chassis	Electronic Brake Control Module																																																									
K	2013	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																									
K	2013	Onix	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2013	Onix	Body	Body Control Module																																																									
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2013	Onix	Body	Instrument Cluster																																																								
K	2013	Onix	Body	Radio																																																								
K	2013	Onix	Body	Parking Assist Control Module																																																								
K	2013	Onix	Body	Remote Function Actuation																																																								
K	2013	Prisma	Powertrain	Engine Control Module																																																								
K	2013	Prisma	Powertrain	Transmission Control Module																																																								
K	2013	Prisma	Chassis	Electronic Brake Control Module																																																								
K	2013	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2013	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2013	Prisma	Body	Body Control Module																																																								
K	2013	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2013	Prisma	Body	Instrument Cluster																																																								
K	2013	Prisma	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2013	Prisma	Body	Parking Assist Control Module																																																										
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2014	Onix	Chassis	Electronic Brake Control Module																																																										
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Onix	Body	Body Control Module																																																										
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Onix	Body	Instrument Cluster																																																										
K	2014	Onix	Body	Radio																																																										
K	2014	Onix	Body	Parking Assist Control Module																																																										
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module																																																										
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2014	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Prisma	Body	Body Control Module																																																										
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Prisma	Body	Instrument Cluster																																																										
K	2014	Prisma	Body	Radio																																																										
K	2014	Prisma	Body	Parking Assist Control Module																																																										
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2015	Onix	Chassis	Electronic Brake Control Module																																																										
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Onix	Body	Body Control Module																																																										
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Onix	Body	Instrument Cluster																																																										
K	2015	Onix	Body	Radio																																																										
K	2015	Onix	Body	Parking Assist Control Module																																																										
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2015	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2015	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Prisma	Body	Body Control Module																																																										
K	2015	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Prisma	Body	Instrument Cluster																																																										
K	2015	Prisma	Body	Radio																																																										
K	2015	Prisma	Body	Parking Assist Control Module																																																										
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2016	Onix	Chassis	Electronic Brake Control Module																																																										
K	2016	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Onix	Body	Body Control Module																																																										
K	2016	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Onix	Body	Instrument Cluster																																																										
K	2016	Onix	Body	Radio																																																										
K	2016	Onix	Body	Parking Assist Control Module																																																										
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2016	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2016	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Prisma	Body	Body Control Module																																																										
K	2016	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Prisma	Body	Instrument Cluster																																																										
K	2016	Prisma	Body	Radio																																																										
K	2016	Prisma	Body	HVAC Control Module																																																										
K	2016	Prisma	Body	Front Seat Heating Control Module																																																										
K	2016	Prisma	Body	Parking Assist Control Module																																																										
L	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																																
L	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2004	ALL	Powertrain	Transmission Control Module																																																										
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																										
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																										
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
L	2004	ALL	Body	ISU																																																									
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
L	2005	ALL	Powertrain	Transmission Control Module																																																									
L	2005	ALL	Chassis	Anti-lock Brake System																																																									
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
L	2005	ALL	Body	ISU																																																									
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																									
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																									
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																									
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
L	2006	ALL	Body	ISU																																																									
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																															
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module										V																																															
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																									
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector																																																									
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																									
L	2007	ALL	Chassis	Electronic Brake Control Module																																																									
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
L	2007	ALL	Body	ISU																																																									
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module										V																																															
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																									
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																									
L	2008	ALL	Chassis	Electronic Brake Control Module																																																									
L	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
L	2008	ALL	Body	ISU																																																									
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module										V																																															
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																									
L	2009	ALL	Chassis	Electronic Brake Control Module																																																									
L	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
L	2009	ALL	Body	ISU																																																									
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module										V																																															
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																									
L	2010	ALL	Chassis	Electronic Brake Control Module																																																									
L	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
L	2010	ALL	Body	ISU																																																									
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module										V																																																	
L	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
L	2011	ALL	Chassis	Electronic Brake Control Module																																																											
L	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2011	ALL	Body	ISU																																																											
M	2004	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																											
M	2004	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																											
M	2004	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
M	2004	ALL	Chassis	Anti-lock Brake System																																																											
M	2004	ALL	Body	Remote Function Actuation																																																											
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
M	2005	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
M	2005	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																											
M	2005	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																											
M	2005	ALL	Chassis	Anti-lock Brake System																																																											
M	2005	ALL	Body	Remote Function Actuation																																																											
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
M	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
M	2006	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																											
M	2006	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																											
M	2006	ALL	Chassis	Anti-lock Brake System																																																											
M	2006	ALL	Body	Remote Function Actuation																																																											
M	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
M	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
M	2007	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																											
M	2007	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																											
M	2007	ALL	Chassis	Anti-lock Brake System																																																											
M	2007	ALL	Body	Remote Function Actuation																																																											
M	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
M	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
M	2008	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																											
M	2008	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																											
M	2008	ALL	Chassis	Anti-lock Brake System																																																											
M	2008	ALL	Body	Remote Function Actuation																																																											
M	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
M	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
M	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																											
M	2009	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																											
M	2009	ALL	Chassis	Anti-lock Brake System																																																											
M	2009	ALL	Body	Remote Function Actuation																																																											
M	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
M	2010	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																	
M	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
M	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
M	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
M	2010	Spark	Powertrain	1.0L LMT Engine Control Module										V																																																
M	2010	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
M	2010	Spark	Powertrain	Transmission Control Module																																																											
M	2010	Spark	Chassis	Electronic Brake Control Module																																																											
M	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
M	2010	Spark	Chassis	Electric Power Steering Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
M	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2010	Spark	Body	Passenger Presence Module																																																										
M	2010	Spark	Body	Instrument Cluster																																																									
M	2011	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																									
M	2011	Caprice	Powertrain	Transmission Control Module																																																									
M	2011	Caprice	Powertrain	Fuel Pump Control Module																																																									
M	2011	Caprice	Chassis	Electronic Brake Control Module																																																									
M	2011	Caprice	Body	Body Control Module																																																									
M	2011	Caprice	Body	HVAC Control Module																																																									
M	2011	Caprice	Body	Instrument Panel Cluster																																																									
M	2011	Caprice	Body	Passenger Presence System																																																									
M	2011	Caprice	Body	Radio																																																									
M	2011	Caprice	Body	Remote Control Door Lock Receiver																																																									
M	2011	Caprice	Body	Supplemental Inflatable Restraint																																																									
M	2011	Caprice	Body	Theft Deterrent Module																										V	V																															
M	2011	Spark	Powertrain	1.0L LCP Engine Control Module										V																																															
M	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																									
M	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																									
M	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																									
M	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module										V																																															
M	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module										V																																															
M	2011	Spark	Powertrain	Transmission Control Module																																																									
M	2011	Spark	Chassis	Electronic Brake Control Module																																																									
M	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
M	2011	Spark	Chassis	Electric Power Steering Control Module																																																									
M	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2011	Spark	Body	Passenger Presence Module																																																									
M	2011	Spark	Body	Instrument Cluster																																																									
M	2012	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																									
M	2012	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																									
M	2012	Caprice	Powertrain	Transmission Control Module																																																									
M	2012	Caprice	Powertrain	Fuel Pump Control Module																																																									
M	2012	Caprice	Chassis	Electronic Brake Control Module																																																									
M	2012	Caprice	Body	Body Control Module																																																									
M	2012	Caprice	Body	HVAC Control Module																																																									
M	2012	Caprice	Body	Instrument Panel Cluster																																																									
M	2012	Caprice	Body	Passenger Presence System																																																									
M	2012	Caprice	Body	Radio																																																									
M	2012	Caprice	Body	Remote Control Door Lock Receiver																																																									
M	2012	Caprice	Body	Supplemental Inflatable Restraint																																																									
M	2012	Caprice	Body	Theft Deterrent Module																										V	V																															
M	2012	Spark	Powertrain	1.0L LCP Engine Control Module										V																																															
M	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																									
M	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																									
M	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																									
M	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module										V																																															
M	2012	Spark	Powertrain	1.19L LC5 Engine Control Module										V																																															

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
M	2012	Spark	Powertrain	1.2L L2E Engine Control Module										V																																																	
M	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module										V																																																	
M	2012	Spark	Powertrain	Transmission Control Module																																																												
M	2012	Spark	Chassis	Electronic Brake Control Module																																																												
M	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
M	2012	Spark	Chassis	Electric Power Steering Control Module																																																												
M	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2012	Spark	Body	Passenger Presence Module																																																												
M	2012	Spark	Body	Instrument Cluster																																																												
M	2013	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																												
M	2013	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																												
M	2013	Caprice	Powertrain	Transmission Control Module																																																												
M	2013	Caprice	Powertrain	Fuel Pump Control Module																																																												
M	2013	Caprice	Chassis	Electronic Brake Control Module																																																												
M	2013	Caprice	Body	Body Control Module																																																												
M	2013	Caprice	Body	HVAC Control Module																																																												
M	2013	Caprice	Body	Instrument Panel Cluster																																																												
M	2013	Caprice	Body	Passenger Presence System																																																												
M	2013	Caprice	Body	Radio																																																											
M	2013	Caprice	Body	Remote Control Door Lock Receiver																																																												
M	2013	Caprice	Body	Supplemental Inflatable Restraint																																																												
M	2013	Caprice	Body	Theft Deterrent Module																										V	V																																	
M	2013	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																		
M	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												
M	2013	Spark	Powertrain	1.0L LMT Engine Control Module										V																																																	
M	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
M	2013	Spark	Powertrain	1.19L LC5 Engine Control Module										V																																																	
M	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																												
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
M	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																												
M	2013	Spark	Powertrain	1.2L L2E Engine Control Module										V																																																		
M	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																												
M	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																												
M	2013	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																		
M	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
M	2013	Spark	Powertrain	Fuel Injector Control Module																																																												
M	2013	Spark	Chassis	Electronic Brake Control Module																																																												
M	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
M	2013	Spark	Chassis	Power Steering Control Module																																																												
M	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
M	2013	Spark	Body	Body Control Module																																																											
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2013	Spark	Body	Passenger Presence Module																																																											
M	2013	Spark	Body	Instrument Cluster																																																											
M	2013	Spark	Body	Radio																																																											
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
M	2014	Spark	Powertrain	0.8L LBF Engine Control Module										V																																																
M	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Engine Control Module										V																																																
M	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																
M	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Engine Control Module										V																																																
M	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2014	Spark	Chassis	Power Steering Control Module																																																										
M	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2014	Spark	Body	Body Control Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Passenger Presence Module																																																										
M	2014	Spark	Body	Instrument Cluster																																																										
M	2014	Spark	Body	Radio																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark	Body	Keyless Entry Control Module						V																																																				
M	2014	Spark EV	Powertrain	Engine Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																												V														
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																												V	V	V	V	V		V	V	V			V	V
M	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
M	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2014	Spark EV	Chassis	Power Steering Control Module																																																										
M	2014	Spark EV	Body	Body Control Module																																																										
M	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark EV	Body	Passenger Presence Module																																																										
M	2014	Spark EV	Body	Instrument Cluster																																																										
M	2014	Spark EV	Body	Radio																																																										
M	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
M	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																									
M	2014	Spark EV	Body	Coolant Heater Control Module																																																									
M	2014	Spark EV	Body	Keyless Entry Control Module																																																									
M	2014	Spark EV	Body	Battery Charger Control Module																																																									
M	2014	Spark EV	Body	DC Charging Control Module																																																									
M	2014	Spark EV	Body	Battery Energy Control Module																																																									
M	2015	Matiz	Powertrain	1.0L LA2 Engine Control Module										V																																															
M	2015	Matiz	Chassis	Electronic Brake Control Module																																																									
M	2015	Matiz	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2015	Matiz	Body	Keyless Entry Control Module						V																																																			
M	2015	Spark	Powertrain	0.8L LBF Engine Control Module										V																																															
M	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																									
M	2015	Spark	Powertrain	1.0L LA2 Engine Control Module										V																																															
M	2015	Spark	Powertrain	1.0L LCP Engine Control Module										V																																															
M	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																									
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																									
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																									
M	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																									
M	2015	Spark	Powertrain	1.0L LMT Engine Control Module										V																																															
M	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																									
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module										V																																															
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																									
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																									
M	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																									
M	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																									
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module										V																																															
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
M	2015	Spark	Powertrain	Fuel Injector Control Module																																																									
M	2015	Spark	Chassis	Electronic Brake Control Module																																																									
M	2015	Spark	Chassis	Electronic Brake Control Module																																																									
M	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
M	2015	Spark	Chassis	Power Steering Control Module																																																									
M	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
M	2015	Spark	Body	Body Control Module																																																									
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2015	Spark	Body	Passenger Presence Module																																																									
M	2015	Spark	Body	Instrument Cluster																																																									
M	2015	Spark	Body	Instrument Cluster																																																									
M	2015	Spark	Body	Tire Pressure Indicator Module																																																									
M	2015	Spark	Body	Radio																																																									
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																									
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																									
M	2015	Spark	Body	Keyless Entry Control Module						V																																																			
M	2015	Spark EV	Powertrain	Engine Control Module																																																									
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																									
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																									
M	2015	Spark EV	Powertrain	Drive Motor Control Module																																																									
M	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
M	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2015	Spark EV	Chassis	Power Steering Control Module																																																										
M	2015	Spark EV	Body	Body Control Module																																																										
M	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Spark EV	Body	Passenger Presence Module																																																										
M	2015	Spark EV	Body	Instrument Cluster																																																										
M	2015	Spark EV	Body	Radio																																																										
M	2015	Spark EV	Body	HVAC Control Module																																																										
M	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2015	Spark EV	Body	Coolant Heater Control Module																																																										
M	2015	Spark EV	Body	Keyless Entry Control Module																																																										
M	2015	Spark EV	Body	Battery Charger Control Module																																																										
M	2015	Spark EV	Body	DC Charging Control Module																																																										
M	2015	Spark EV	Body	Battery Energy Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Engine Control Module										V																																																
M	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.0L LA2 Engine Control Module										V																																																
M	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	1.0L LCP Engine Control Module										V																																																
M	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.0L LMT Engine Control Module										V																																																
M	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
M	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module										V																																																
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2016	Spark	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2016	Spark	Chassis	Power Steering Control Module																																																										
M	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2016	Spark	Body	Body Control Module																																			V																						
M	2016	Spark	Body	Body Control Module																																																									
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Instrument Cluster																																																										
M	2016	Spark	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
M	2016	Spark	Body	Radio																																																									
M	2016	Spark	Body	Telematics Communication Interface Control Module																																																									
M	2016	Spark	Body	Keyless Entry Control Module						V																																																			
M	2016	Spark EV	Powertrain	Engine Control Module																																																									
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																												V													
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																												V	V	V	V	V		V	V	V			V	V
M	2016	Spark EV	Powertrain	Drive Motor Control Module																																																									
M	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																									
M	2016	Spark EV	Chassis	Electronic Brake Control Module																																																									
M	2016	Spark EV	Chassis	Parking Brake Control Module																																																									
M	2016	Spark EV	Chassis	Power Steering Control Module																																																									
M	2016	Spark EV	Body	Body Control Module																																																									
M	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																									
M	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2016	Spark EV	Body	Passenger Presence Module																																																									
M	2016	Spark EV	Body	Instrument Cluster																																																									
M	2016	Spark EV	Body	Radio																																																									
M	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																									
M	2016	Spark EV	Body	HVAC Control Module																																																									
M	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																									
M	2016	Spark EV	Body	Coolant Heater Control Module																																																									
M	2016	Spark EV	Body	Keyless Entry Control Module																																																									
M	2016	Spark EV	Body	Frontview Camera Module																																																									
M	2016	Spark EV	Body	Battery Charger Control Module																																																									
M	2016	Spark EV	Body	DC Charging Control Module																																																									
M	2016	Spark EV	Body	Battery Energy Control Module																																																									
N	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																															
N	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module										V																																															
N	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module										V																																															
N	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
N	2004	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
N	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																									
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																									
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																									
N	2004	Optra	Body	Remote Function Actuation																																																									
N	2004	Optra	Body	Supplemental Inflatable Restraint																																																									
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module											V																																														
N	2004	Classic	Chassis	Anti-lock Brake System																																																									
N	2004	Classic	Body	Body Control Module																																																									
N	2004	Classic	Body	Radio																																																									
N	2004	Classic	Body	Remote Function Actuation																																																									
N	2004	Classic	Body	Supplemental Inflatable Restraint												V	V																																												
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Engine Control Module										V																																															
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Transmission Control Module											V																																														
N	2004	Alero (Export)	Chassis	Anti-lock Brake System																																																									
N	2004	Alero (Export)	Body	Body Control Module																																																									
N	2004	Alero (Export)	Body	Instrument Panel Cluster																																																									
N	2004	Alero (Export)	Body	Radio																	V	V																																							

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
N	2004	Alero (Export)	Body	Supplemental Inflatable Restraint												V	V																																													
N	2004	Alero (Export)	Body	Vehicle Theft Deterrent																																																										
N	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																															
N	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module										V																																															
N	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module										V																																															
N	2005	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
N	2005	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
N	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																									
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																									
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																									
N	2005	Optra	Body	Remote Function Actuation																																																									
N	2005	Optra	Body	Supplemental Inflatable Restraint																																																									
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module											V																																														
N	2005	Classic	Chassis	Anti-lock Brake System																																																									
N	2005	Classic	Body	Body Control Module																																																								
N	2005	Classic	Body	Radio																																																								
N	2005	Classic	Body	Remote Function Actuation																																																								
N	2005	Classic	Body	Supplemental Inflatable Restraint																																																								
N	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																															
N	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																															
N	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module										V																																															
N	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module										V																																															
N	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
N	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
N	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																									
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																									
N	2006	ALL	Body	Remote Function Actuation																																																									
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																															
N	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																															
N	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module										V																																															
N	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																															
N	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
N	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
N	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																									
N	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																									
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																									
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																									
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																									
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																									
N	2007	ALL	Chassis	Tire Pressure Monitor																																																									
N	2007	ALL	Body	Remote Function Actuation																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
N	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
N	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
N	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
N	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																																
N	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module										V																																																
N	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																																
N	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module										V																																																
N	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																																
N	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																										
N	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2008	ALL	Chassis	Tire Pressure Monitor																																																										
N	2008	ALL	Body	Remote Function Actuation																																																										
N	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
N	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																																
N	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module										V																																																
N	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																																
N	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																																
N	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																										
N	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2009	ALL	Chassis	Tire Pressure Monitor																																																										
N	2009	ALL	Body	Remote Function Actuation																																																										
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2010	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
N	2010	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																																
N	2010	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																																
N	2010	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																																
N	2010	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2010	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2010	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2010	ALL	Chassis	Tire Pressure Monitor																																																										
N	2010	ALL	Body	Remote Function Actuation																																																										
N	2010	ALL	Body	Remote Function Actuation																																																										
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
N	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
N	2011	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																																
N	2011	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																																
N	2011	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																																
N	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2011	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2011	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2011	ALL	Chassis	Tire Pressure Monitor																																																										
N	2011	ALL	Body	Remote Function Actuation																																																										
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2012	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2012	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
N	2012	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																																
N	2012	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																																
N	2012	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2012	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2012	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2012	ALL	Chassis	Tire Pressure Monitor																																																										
N	2012	ALL	Body	Remote Function Actuation																																																										
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2013	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2013	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
N	2013	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																																
N	2013	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module										V																																																
N	2013	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2013	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2013	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2013	ALL	Chassis	Tire Pressure Monitor																																																										
N	2013	ALL	Body	Remote Function Actuation																																																										
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
N	2014	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
N	2014	Caprice	Powertrain	(2) 6.0L L77 Chassis Control Module																																																										
N	2014	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
N	2014	Caprice	Chassis	Electronic Brake Control Module																																																										
N	2014	Caprice	Chassis	Parking Brake Control Module																																																										
N	2014	Caprice	Chassis	Power Steering Control Module																																																										
N	2014	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2014	Caprice	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
N	2014	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2014	Caprice	Body	Passenger Presence Module																																																										
N	2014	Caprice	Body	Instrument Cluster																																																										
N	2014	Caprice	Body	Radio Controls																																																										
N	2014	Caprice	Body	HVAC Controls																																																										
N	2014	Caprice	Body	Headlamp Control Module																																																										
N	2014	Caprice	Body	Trailer Interface Control Module																																																										
N	2014	Caprice	Body	Radio																																																										
N	2014	Caprice	Body	HVAC Control Module																																																										
N	2014	Caprice	Body	Parking Assist Control Module																																																										
N	2014	Caprice	Body	Frontview Camera Module																																																										
N	2014	Caprice	Body	Steering Column Lock Control Module																																																										
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
N	2015	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
N	2015	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
N	2015	Caprice	Powertrain	Fuel Injector Control Module																																																										
N	2015	Caprice	Chassis	Electronic Brake Control Module																																																										
N	2015	Caprice	Chassis	Parking Brake Control Module																																																										
N	2015	Caprice	Chassis	Power Steering Control Module																																																										
N	2015	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2015	Caprice	Chassis	Suspension Control Module																																																										
N	2015	Caprice	Body	Body Control Module																																																										
N	2015	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2015	Caprice	Body	Passenger Presence Module																																																										
N	2015	Caprice	Body	Instrument Cluster																																																										
N	2015	Caprice	Body	Head-Up Display Module																																																										
N	2015	Caprice	Body	Radio Controls																																																										
N	2015	Caprice	Body	HVAC Controls																																																										
N	2015	Caprice	Body	Headlamp Control Module																																																										
N	2015	Caprice	Body	Trailer Interface Control Module																																																										
N	2015	Caprice	Body	Radio																																																										
N	2015	Caprice	Body	Telematics Communication Interface Control Module																																																										
N	2015	Caprice	Body	HVAC Control Module																																																										
N	2015	Caprice	Body	Right Side Object Detection Control Module																																																										
N	2015	Caprice	Body	Left Side Object Detection Control Module																																																										
N	2015	Caprice	Body	Parking Assist Control Module																																																										
N	2015	Caprice	Body	Frontview Camera Module																																																										
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
N	2016	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
N	2016	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
N	2016	Caprice	Powertrain	Fuel Injector Control Module																																																										
N	2016	Caprice	Chassis	Electronic Brake Control Module																																																										
N	2016	Caprice	Chassis	Parking Brake Control Module																																																										
N	2016	Caprice	Chassis	Power Steering Control Module																																																										
N	2016	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
N	2016	Caprice	Chassis	Suspension Control Module																																																									
N	2016	Caprice	Body	Body Control Module																																																									
N	2016	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2016	Caprice	Body	Passenger Presence Module																																																									
N	2016	Caprice	Body	Instrument Cluster																																																									
N	2016	Caprice	Body	Head-Up Display Module																																																									
N	2016	Caprice	Body	Radio Controls																																																									
N	2016	Caprice	Body	HVAC Controls																																																									
N	2016	Caprice	Body	Trailer Interface Control Module																																																									
N	2016	Caprice	Body	Radio																																																									
N	2016	Caprice	Body	Telematics Communication Interface Control Module																																																									
N	2016	Caprice	Body	HVAC Control Module																																																									
N	2016	Caprice	Body	Seat Memory Control Module - Driver																																																									
N	2016	Caprice	Body	Right Side Object Detection Control Module																																																									
N	2016	Caprice	Body	Left Side Object Detection Control Module																																																									
N	2016	Caprice	Body	Parking Assist Control Module																																																									
N	2016	Caprice	Body	Frontview Camera Module																																																									
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																									
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission										V																																															
P	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																									
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																									
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																									
P	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																									
P	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																									
P	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																									
P	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																									
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																									
P	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																									
P	2010	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2010	Cruze	Body	Body Control Module																																																									
P	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2010	Cruze	Body	Passenger Presence Module																																																									
P	2010	Cruze	Body	Instrument Cluster																																																									
P	2010	Cruze	Body	Trailer Interface Control Module																																																									
P	2010	Cruze	Body	Radio																																																									
P	2010	Cruze	Body	Multimedia Player Interface Module																																																									
P	2010	Cruze	Body	Mobile Telephone Control Module																																																									
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
P	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
P	2010	Cruze	Body	Keyless Entry Control Module																																																									
P	2010	Cruze	Body	Parking Assist Control Module																																																									
P	2010	Cruze	Body	Steering Column Lock Control Module																																																									
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																									
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																									
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission										V																																																		
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission										V																																																		
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																												
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																												
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																												
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																												
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																												
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission										V																																																		
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission										V																																																		
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																												
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																												
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																												
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																												
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																												
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																												
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																												
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission										V																																																		
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																																		
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2011	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2011	Cruze	Body	Body Control Module																																																												
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2011	Cruze	Body	Passenger Presence Module																																																												
P	2011	Cruze	Body	Instrument Cluster																																																												
P	2011	Cruze	Body	Trailer Interface Control Module																																																												
P	2011	Cruze	Body	Radio																																																											
P	2011	Cruze	Body	Multimedia Player Interface Module																																																											
P	2011	Cruze	Body	Mobile Telephone Control Module																																																											
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2011	Cruze	Body	Keyless Entry Control Module																																																											
P	2011	Cruze	Body	Parking Assist Control Module																																																											
P	2011	Cruze	Body	Steering Column Lock Control Module																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																											
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission										V																																																		
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission										V																																																		

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
P	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																										
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																										
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																										
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																										
P	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																										
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission										V																																															
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission										V																																															
P	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																															
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																															
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																										
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																										
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																										
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																										
P	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
P	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
P	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
P	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																										
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																										
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission										V																																															
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission										V																																															
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																										
P	2012	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2012	Cruze	Body	Body Control Module Hatchback																																																										
P	2012	Cruze	Body	Body Control Module Sedan																																																										
P	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2012	Cruze	Body	Passenger Presence Module																																																										
P	2012	Cruze	Body	Instrument Cluster																																																										
P	2012	Cruze	Body	Trailer Interface Control Module																																																										
P	2012	Cruze	Body	Radio																																																										
P	2012	Cruze	Body	Multimedia Player Interface Module																																																										
P	2012	Cruze	Body	Mobile Telephone Control Module																																																										
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
P	2012	Cruze	Body	Keyless Entry Control Module																																																										
P	2012	Cruze	Body	Parking Assist Control Module																																																										
P	2012	Cruze	Body	Steering Column Lock Control Module																																																										
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission										V																																																
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission										V																																																
P	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission										V																																																
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission										V																																																
P	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																																
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																																
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission										V																																																
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																																
P	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2013	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2013	Cruze	Body	Body Control Module Hatchback																																																										
P	2013	Cruze	Body	Body Control Module Sedan																																																										
P	2013	Cruze	Body	Body Control Module Station Wagon																																																										
P	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2013	Cruze	Body	Passenger Presence Module																																																										
P	2013	Cruze	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
P	2013	Cruze	Body	Trailer Interface Control Module																																																										
P	2013	Cruze	Body	Radio																																																										
P	2013	Cruze	Body	Digital Radio Receiver Control Module																																																										
P	2013	Cruze	Body	Multimedia Player Interface Module																																																										
P	2013	Cruze	Body	Mobile Telephone Control Module																																																										
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
P	2013	Cruze	Body	Front Seat Heating Control Module																																																										
P	2013	Cruze	Body	Keyless Entry Control Module																																																										
P	2013	Cruze	Body	Right Side Object Detection Control Module																																																										
P	2013	Cruze	Body	Left Side Object Detection Control Module																																																										
P	2013	Cruze	Body	Parking Assist Control Module																																																										
P	2013	Cruze	Body	Steering Column Lock Control Module																																																										
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission										V																																															
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission										V																																															
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission										V																																															
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission										V																																															
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission										V																																															
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission										V																																															
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																															
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																															
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission										V																																															
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																															
P	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module										V																																															
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																										
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																										
P	2014	Cruze	Powertrain	Fuel Injector Control Module																																																										
P	2014	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2014	Cruze	Chassis	Power Steering Control Module																																																										
P	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2014	Cruze	Body	Body Control Module Hatchback																																																										
P	2014	Cruze	Body	Body Control Module Sedan																																																										
P	2014	Cruze	Body	Body Control Module Station Wagon																																																										
P	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2014	Cruze	Body	Passenger Presence Module																																																										
P	2014	Cruze	Body	Instrument Cluster																																																										
P	2014	Cruze	Body	Trailer Interface Control Module																																																										
P	2014	Cruze	Body	Radio																																																										
P	2014	Cruze	Body	Digital Radio Receiver Control Module																																																										
P	2014	Cruze	Body	Multimedia Player Interface Module																																																										
P	2014	Cruze	Body	Mobile Telephone Control Module																																																										
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
P	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
P	2014	Cruze	Body	Front Seat Heating Control Module																																																										
P	2014	Cruze	Body	Keyless Entry Control Module																																																										
P	2014	Cruze	Body	Right Side Object Detection Control Module																																																										
P	2014	Cruze	Body	Left Side Object Detection Control Module																																																										
P	2014	Cruze	Body	Parking Assist Control Module																																																										
P	2014	Cruze	Body	Steering Column Lock Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission										V																																															
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission										V																																															
P	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission										V																																															
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission										V																																															
P	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission										V																																															
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission										V																																															
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																															
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																															
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission										V																																															
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																															
P	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module										V																																															
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																										
P	2015	Cruze	Powertrain	Fuel Injector Control Module																																																										
P	2015	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2015	Cruze	Chassis	Power Steering Control Module																																																										
P	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2015	Cruze	Body	Body Control Module Hatchback																																																										
P	2015	Cruze	Body	Body Control Module Sedan																																																										
P	2015	Cruze	Body	Body Control Module Station Wagon																																																										
P	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2015	Cruze	Body	Passenger Presence Module																																																										
P	2015	Cruze	Body	Instrument Cluster																																																										
P	2015	Cruze	Body	Trailer Interface Control Module																																																										
P	2015	Cruze	Body	Radio																																																										
P	2015	Cruze	Body	Digital Radio Receiver Control Module																																																										
P	2015	Cruze	Body	Multimedia Player Interface Module																																																										
P	2015	Cruze	Body	Mobile Telephone Control Module																																																										
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
P	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
P	2015	Cruze	Body	Front Seat Heating Control Module																																																										
P	2015	Cruze	Body	Keyless Entry Control Module																																																										
P	2015	Cruze	Body	Right Side Object Detection Control Module																																																										
P	2015	Cruze	Body	Left Side Object Detection Control Module																																																										
P	2015	Cruze	Body	Parking Assist Control Module																																																										
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2016	Cruze	Powertrain	Fuel Injector Control Module																																																										
P	2016	Cruze	Powertrain	Chassis Control Module																																																										
P	2016	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2016	Cruze	Chassis	Power Steering Control Module																																																										
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2016	Cruze	Body	Body Control Module Hatchback																																																										
P	2016	Cruze	Body	Body Control Module Sedan																																																										
P	2016	Cruze	Body	Body Control Module Station Wagon																																																										
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2016	Cruze	Body	Passenger Presence Module																																																										
P	2016	Cruze	Body	Instrument Cluster																																																										
P	2016	Cruze	Body	Trailer Interface Control Module																																																										
P	2016	Cruze	Body	Radio Other																																																										
P	2016	Cruze	Body	Radio (UF7)																																																										
P	2016	Cruze	Body	Multimedia Player Interface Module																																																										
P	2016	Cruze	Body	Mobile Telephone Control Module																																																										
P	2016	Cruze	Body	Telematics Communication Interface Control Module																																																										
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																										
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																										
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																										
P	2016	Cruze	Body	Front Seat Heating Control Module																																																										
P	2016	Cruze	Body	Keyless Entry Control Module																																																										
P	2016	Cruze	Body	Right Side Object Detection Control Module																																																										
P	2016	Cruze	Body	Left Side Object Detection Control Module																																																										
P	2016	Cruze	Body	Parking Assist Control Module																																																										
P	2016	Cruze	Body	Steering Column Lock Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2011	Volt	Powertrain	Engine Control Module																																																										
R	2011	Volt	Powertrain	Trasmission Control Module																																																											
R	2011	Volt	Powertrain	Fuel Pump Control Module																																																											
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module																																												V														
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module 2																																												V	V	V	V	V		V	V	V	V	V	V	
R	2011	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2011	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2011	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2011	Volt	Chassis	Electronic Brake Control Module																																																										
R	2011	Volt	Chassis	Parking Brake Control Module																																																										
R	2011	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2011	Volt	Chassis	Power Steering Control Module																																																										
R	2011	Volt	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2011	Volt	Body	Body Control Module																																																										
R	2011	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2011	Volt	Body	Passenger Presence Module																																																										
R	2011	Volt	Body	Instrument Cluster																																																										
R	2011	Volt	Body	Radio																																																										
R	2011	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2011	Volt	Body	Mobile Telephone Control Module																																																										
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2011	Volt	Body	Remote Heater and Air Conditioning Control Module																																																										
R	2011	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2011	Volt	Body	Coolant Heater Control Module																																																										
R	2011	Volt	Body	Keyless Entry Control Module																																																										
R	2011	Volt	Body	Parking Assist Control Module																																																										
R	2011	Volt	Body	Steering Column Lock Control Module																																																										
R	2011	Volt	Body	Battery Charger Control Module																																																										
R	2011	Volt	Body	Battery Energy Control Module																																																										
R	2012	Volt	Powertrain	Engine Control Module																																																										
R	2012	Volt	Powertrain	Trasmission Control Module																																																										
R	2012	Volt	Powertrain	Fuel Pump Control Module																																																										
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module																																												V														
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module 2																																												V	V	V	V	V		V	V	V	V	V	V	
R	2012	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2012	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2012	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2012	Volt	Chassis	Electronic Brake Control Module																																																										
R	2012	Volt	Chassis	Parking Brake Control Module																																																										
R	2012	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2012	Volt	Chassis	Power Steering Control Module																																																										
R	2012	Volt	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2012	Volt	Body	Body Control Module																																																										
R	2012	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2012	Volt	Body	Passenger Presence Module																																																										
R	2012	Volt	Body	Instrument Cluster																																																										
R	2012	Volt	Body	Radio																																																										
R	2012	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2012	Volt	Body	Mobile Telephone Control Module																																																										
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 9																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 10																																																									
R	2012	Volt	Body	Remote Heater and Air Conditioning Control Module																																																									
R	2012	Volt	Body	Electric A/C Compressor Control Module																																																									
R	2012	Volt	Body	Coolant Heater Control Module																																																									
R	2012	Volt	Body	Keyless Entry Control Module																																																									
R	2012	Volt	Body	Parking Assist Control Module																																																									
R	2012	Volt	Body	Steering Column Lock Control Module																																																									
R	2012	Volt	Body	Battery Charger Control Module																																																									
R	2012	Volt	Body	Battery Energy Control Module																																																									
R	2013	Volt	Powertrain	Engine Control Module																																																									
R	2013	Volt	Powertrain	Trasmission Control Module																																																									
R	2013	Volt	Powertrain	Fuel Pump Control Module																																																									
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module																																													V													
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module 2																																													V	V	V	V	V		V	V	V	V	V	V	V
R	2013	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2013	Volt	Powertrain	Drive Motor Control Module 2																																																									
R	2013	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																									
R	2013	Volt	Chassis	Electronic Brake Control Module																																																									
R	2013	Volt	Chassis	Parking Brake Control Module																																																									
R	2013	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																									
R	2013	Volt	Chassis	Power Steering Control Module																																																									
R	2013	Volt	Chassis	Steering Wheel Angle Sensor Module																																																									
R	2013	Volt	Body	Body Control Module																																																									
R	2013	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
R	2013	Volt	Body	Passenger Presence Module																																																									
R	2013	Volt	Body	Instrument Cluster																																																									
R	2013	Volt	Body	Radio																																																									
R	2013	Volt	Body	Digital Radio Receiver Control Module																																																									
R	2013	Volt	Body	Multimedia Player Interface Module																																																									
R	2013	Volt	Body	Mobile Telephone Control Module																																																									
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 9																																																									
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 10																																																									
R	2013	Volt	Body	HVAC Control Module																																																									
R	2013	Volt	Body	Electric A/C Compressor Control Module																																																									
R	2013	Volt	Body	Coolant Heater Control Module																																																									
R	2013	Volt	Body	Front Seat Heating Control Module																																																									
R	2013	Volt	Body	Keyless Entry Control Module																																																									
R	2013	Volt	Body	Parking Assist Control Module																																																									
R	2013	Volt	Body	Frontview Camera Module																																																									
R	2013	Volt	Body	Steering Column Lock Control Module																																																									
R	2013	Volt	Body	Battery Charger Control Module																																																									
R	2013	Volt	Body	Battery Energy Control Module																																																									
R	2014	Volt	Powertrain	Engine Control Module																																																									
R	2014	Volt	Powertrain	Trasmission Control Module																																																									
R	2014	Volt	Powertrain	Chassis Control Module																																																									
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module																																													V													
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module 2																																													V	V	V	V	V	V	V	V	V	V	V	V	V
R	2014	Volt	Powertrain	Drive Motor Control Module 1																																																									
R	2014	Volt	Powertrain	Drive Motor Control Module 2																																																									
R	2014	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																									
R	2014	Volt	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2014	Volt	Chassis	Parking Brake Control Module																																																										
R	2014	Volt	Chassis	Power Steering Control Module																																																										
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2014	Volt	Body	Body Control Module																																																										
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2014	Volt	Body	Passenger Presence Module																																																										
R	2014	Volt	Body	Instrument Cluster																																																										
R	2014	Volt	Body	Radio																																																										
R	2014	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	Volt	Body	HVAC Control Module																																																										
R	2014	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2014	Volt	Body	Coolant Heater Control Module																																																										
R	2014	Volt	Body	Front Seat Heating Control Module																																																										
R	2014	Volt	Body	Keyless Entry Control Module																																																										
R	2014	Volt	Body	Parking Assist Control Module																																																										
R	2014	Volt	Body	Frontview Camera Module																																																										
R	2014	Volt	Body	Steering Column Lock Control Module																																																										
R	2014	Volt	Body	Battery Charger Control Module																																																										
R	2014	Volt	Body	Battery Energy Control Module																																																										
R	2015	Volt	Powertrain	Engine Control Module																																																										
R	2015	Volt	Powertrain	Trasmission Control Module																																																										
R	2015	Volt	Powertrain	Chassis Control Module																																																										
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module																																														V												
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2																																														V	V	V	V	V	V	V	V	V	V	V	V	V
R	2015	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2015	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2015	Volt	Chassis	Electronic Brake Control Module																																																										
R	2015	Volt	Chassis	Parking Brake Control Module																																																										
R	2015	Volt	Chassis	Power Steering Control Module																																																										
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2015	Volt	Body	Body Control Module																																																										
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	Volt	Body	Passenger Presence Module																																																										
R	2015	Volt	Body	Instrument Cluster																																																										
R	2015	Volt	Body	Radio																																																										
R	2015	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2015	Volt	Body	Telematics Communication Interface Control Module																																																										
R	2015	Volt	Body	HVAC Control Module																																																										
R	2015	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2015	Volt	Body	Coolant Heater Control Module																																																										
R	2015	Volt	Body	Front Seat Heating Control Module																																																										
R	2015	Volt	Body	Keyless Entry Control Module																																																										
R	2015	Volt	Body	Parking Assist Control Module																																																										
R	2015	Volt	Body	Frontview Camera Module																																																										
R	2015	Volt	Body	Steering Column Lock Control Module																																																										
R	2015	Volt	Body	Battery Charger Control Module																																																										
R	2015	Volt	Body	Battery Energy Control Module																																																										
R	2016	Volt	Powertrain	Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module																																												V													
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module 2																																												V	V	V	V	V	V	V		V	V	V	V	V
R	2016	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2016	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2016	Volt	Chassis	Electronic Brake Control Module																																	V	V																						
R	2016	Volt	Chassis	Brake Booster Control Module																																																								
R	2016	Volt	Chassis	Power Steering Control Module																																																								
R	2016	Volt	Body	Body Control Module																																																								
R	2016	Volt	Body	Pedestrian Alert Sound Control Module																																																								
R	2016	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2016	Volt	Body	Passenger Presence Module																																																								
R	2016	Volt	Body	Instrument Cluster																																																								
R	2016	Volt	Body	Radio Controls																																																								
R	2016	Volt	Body	HVAC Controls																																																								
R	2016	Volt	Body	Radio																																																								
R	2016	Volt	Body	Amplifier																																																								
R	2016	Volt	Body	Human Machine Interface Control Module																																																								
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 9.7																																																								
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2016	Volt	Body	HVAC Control Module																																																								
R	2016	Volt	Body	Electric A/C Compressor Control Module																																																								
R	2016	Volt	Body	Keyless Entry Control Module																																																								
R	2016	Volt	Body	Right Side Object Detection Control Module																																																								
R	2016	Volt	Body	Left Side Object Detection Control Module																																																								
R	2016	Volt	Body	Parking Assist Control Module																																																								
R	2016	Volt	Body	Frontview Camera Module																																																								
R	2016	Volt	Body	Steering Column Lock Control Module																																																								
R	2016	Volt	Body	Battery Energy Control Module																																																								
R	2016	Volt	Body	Long Range Radar Sensor Module																																																								
S	2004	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2004	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								
S	2004	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																													
S	2004	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module										V																																													
S	2004	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																													
S	2004	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module										V																																													
S	2004	Aveo	Powertrain	Transmission Control Module																																																								
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2004	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2004	Aveo	Body	Remote Function Actuation																																																								
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2005	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								
S	2005	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																													
S	2005	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module										V																																													
S	2005	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																													
S	2005	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module										V																																													
S	2005	Aveo	Powertrain	Transmission Control Module																																																								
S	2005	Aveo	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2005	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2005	Aveo	Body	Remote Function Actuation																																																										
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2006	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																															
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India										V																																															
S	2006	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module										V																																															
S	2006	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																															
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module										V																																															
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																															
S	2006	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2006	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2006	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2006	Aveo	Body	Remote Function Actuation																																																										
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2007	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																															
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India										V																																															
S	2007	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module										V																																															
S	2007	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																															
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module										V																																															
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																															
S	2007	Aveo	Powertrain	Transmission Control Module 4 Speed																																																										
S	2007	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2007	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2007	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2007	Aveo	Body	Remote Function Actuation																																																										
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2008	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2008	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																															
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India										V																																															
S	2008	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2008	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																															
S	2008	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																															
S	2008	Aveo	Powertrain	Transmission Control Module																																																										
S	2008	Aveo	Powertrain	Transmission Control Module																																																										
S	2008	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2008	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2008	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2008	Aveo	Body	Remote Function Actuation																																																										
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2009	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																															
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India										V																																															
S	2009	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2009	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																															

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2009	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
S	2009	Aveo	Powertrain	Transmission Control Module																																																										
S	2009	Aveo	Powertrain	Transmission Control Module																																																										
S	2009	Aveo	Powertrain	Other Auto Transmission System																																																										
S	2009	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2009	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2009	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2009	Aveo	Body	Remote Function Actuation																																																										
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2010	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2010	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																															
S	2010	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2010	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																															
S	2010	Aveo	Powertrain	(6)1.6L L4 LXT Engine Control Module										V																																															
S	2010	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2010	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2010	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2010	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2010	Aveo	Body	Remote Function Actuation																																																										
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																															
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																															
S	2010	Sail	Powertrain	1.4L LCU Engine Control Module										V																																															
S	2010	Sail	Powertrain	Transmission Control Module																																																										
S	2010	Sail	Chassis	Electronic Brake Control Module																																																										
S	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2011	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2011	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																															
S	2011	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2011	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																															
S	2011	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
S	2011	Aveo	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																										
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2011	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2011	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2011	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2011	Aveo	Body	Remote Function Actuation																																																										
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission										V																																															
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission										V																																															
S	2011	Sail	Powertrain	1.4L LCU Engine Control Module										V																																															
S	2011	Sail	Powertrain	Transmission Control Module																																																										
S	2011	Sail	Chassis	Electronic Brake Control Module																																																										
S	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																											
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																											
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																											
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
S	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																																	
S	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																											
S	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																																	
S	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module										V																																																	
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																											
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																											
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
S	2012	Aveo	Powertrain	Fuel Pump Control Module																																																											
S	2012	Aveo	Powertrain	Fuel Injector Control Module																																																											
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2012	Aveo	Chassis	Electric Power Steering Control Module																																																											
S	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2012	Aveo	Chassis	Tire Pressure Monitor																																																											
S	2012	Aveo	Body	Body Control Module Hatchback																																																											
S	2012	Aveo	Body	Body Control Module Sedan																																																											
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2012	Aveo	Body	Passenger Presence Module																																																											
S	2012	Aveo	Body	Instrument Cluster																																																											
S	2012	Aveo	Body	Radio																																																										
S	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																											
S	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
S	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
S	2012	Aveo	Body	Front Seat Heating Control Module																																																											
S	2012	Aveo	Body	Remote Function Actuation																																																											
S	2012	Aveo	Body	Parking Assist Control Module																																																											
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																											
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission										V																																																	
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission										V																																																	
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission										V																																																	
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission										V																																																	
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																																	
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																																	
S	2012	Sail	Powertrain	Transmission Control Module																																																												
S	2012	Sail	Chassis	Electronic Brake Control Module																																																											
S	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																											
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
S	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																																	
S	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																											
S	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																																	
S	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module										V																																																	
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
S	2013	Aveo	Powertrain	Fuel Injector Control Module																																																											
S	2013	Aveo	Powertrain	Fuel Pump Control Module																																																											
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2013	Aveo	Chassis	Electric Power Steering Control Module																																																											
S	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2013	Aveo	Body	Body Control Module Hatchback																																																											
S	2013	Aveo	Body	Body Control Module Sedan																																																											
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2013	Aveo	Body	Passenger Presence Module																																																											
S	2013	Aveo	Body	Instrument Cluster																																																											
S	2013	Aveo	Body	Radio																																																											
S	2013	Aveo	Body	Telematics Communication Interface Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2013	Aveo	Body	Front Seat Heating Control Module																																																										
S	2013	Aveo	Body	Remote Function Actuation																																																										
S	2013	Aveo	Body	Parking Assist Control Module																																																										
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																															
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																															
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																															
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																															
S	2013	Sail	Powertrain	Transmission Control Module																																																										
S	2013	Sail	Chassis	Electronic Brake Control Module																																																										
S	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Aveo	Powertrain	1.2L LMU Engine Control Module										V																																															
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L L95 Engine Control Module										V																																															
S	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module										V																																															
S	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
S	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module										V																																															
S	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
S	2014	Aveo	Powertrain	Chassis Control Module																																																										
S	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2014	Aveo	Chassis	Power Steering Control Module																																																										
S	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2014	Aveo	Body	Body Control Module Hatchback																																																										
S	2014	Aveo	Body	Body Control Module Sedan																																																										
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Aveo	Body	Instrument Cluster																																																										
S	2014	Aveo	Body	Radio																																																										
S	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
S	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2014	Aveo	Body	Front Seat Heating Control Module																																																										
S	2014	Aveo	Body	Keyless Entry Control Module						V																																																			
S	2014	Aveo	Body	Parking Assist Control Module																																																										
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																															
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																															
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																															
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																															
S	2014	Sail	Powertrain	Transmission Control Module																																																										
S	2014	Sail	Chassis	Electronic Brake Control Module																																																										
S	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Aveo	Powertrain	1.2L LMU Engine Control Module										V																																															
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L L95 Engine Control Module										V																																															
S	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module										V																																																	
S	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																											
S	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module										V																																																	
S	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
S	2015	Aveo	Powertrain	Chassis Control Module																																																												
S	2015	Aveo	Powertrain	Fuel Injector Control Module																																																												
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2015	Aveo	Chassis	Power Steering Control Module																																																											
S	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2015	Aveo	Body	Body Control Module Hatchback																																																											
S	2015	Aveo	Body	Body Control Module Sedan																																																											
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2015	Aveo	Body	Instrument Cluster																																																											
S	2015	Aveo	Body	Radio																																																										
S	2015	Aveo	Body	Telematics Communication Interface Control Module																																																											
S	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
S	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
S	2015	Aveo	Body	Front Seat Heating Control Module																																																											
S	2015	Aveo	Body	Keyless Entry Control Module						V																																																					
S	2015	Aveo	Body	Parking Assist Control Module																																																											
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																																	
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																																	
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																																	
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																																	
S	2015	Sail	Powertrain	Transmission Control Module																																																											
S	2015	Sail	Chassis	Electronic Brake Control Module																																																											
S	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L L95 Engine Control Module										V																																																
S	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module										V																																																
S	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module										V																																																
S	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
S	2016	Aveo	Powertrain	Chassis Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Power Steering Control Module																																																										
S	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	Aveo	Body	Body Control Module Hatchback																																																										
S	2016	Aveo	Body	Body Control Module Sedan																																																										
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Body	Instrument Cluster																																																										
S	2016	Aveo	Body	Radio																																																										
S	2016	Aveo	Body	Telematics Communication Interface Control Module																																																										
S	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2016	Aveo	Body	Front Seat Heating Control Module																																																										
S	2016	Aveo	Body	Parking Assist Control Module																																																										
S	2016	Aveo	Body	Keyless Entry Control Module						V																																																				
S	2016	Aveo	Body	Frontview Camera Module																																																										
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																															
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																															

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																												
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																																		
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																																		
S	2016	Sail	Powertrain	Transmission Control Module																																																												
S	2016	Sail	Chassis	Electronic Brake Control Module																																																												
S	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2004	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																												
T	2004	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																																		
T	2004	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module										V																																																		
T	2004	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																																		
T	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module										V																																																		
T	2004	ALL	Powertrain	Transmission Control Module																																																												
T	2004	ALL	Chassis	Electronic Brake Control Module																																																												
T	2004	ALL	Chassis	Electronic Brake Control Module																																																												
T	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2004	ALL	Body	Remote Function Actuation																																																												
T	2005	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																												
T	2005	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																																		
T	2005	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module										V																																																		
T	2005	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																																		
T	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module										V																																																		
T	2005	ALL	Powertrain	Transmission Control Module																																																												
T	2005	ALL	Chassis	Electronic Brake Control Module																																																												
T	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2005	ALL	Body	Remote Function Actuation																																																												
T	2006	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																												
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																																		
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India										V																																																		
T	2006	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module										V																																																		
T	2006	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																																		
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module										V																																																		
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																																		
T	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
T	2006	ALL	Chassis	Electronic Brake Control Module																																																												
T	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2006	ALL	Body	Remote Function Actuation																																																												
T	2007	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																												
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																																		
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India										V																																																		
T	2007	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module										V																																																		
T	2007	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																																		
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module										V																																																		
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																																		
T	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																												
T	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
T	2007	ALL	Chassis	Electronic Brake Control Module																																																												
T	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2007	ALL	Body	Remote Function Actuation																																																												
T	2008	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
T	2008	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																												
T	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India										V																																																		

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2008	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module										V																																																
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India										V																																																
T	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module										V																																																
T	2008	ALL	Powertrain	Transmission Control Module																																																										
T	2008	ALL	Powertrain	Transmission Control Module																																																										
T	2008	ALL	Chassis	Electronic Brake Control Module																																																										
T	2008	ALL	Chassis	Tire Pressure Monitor																																																										
T	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2008	ALL	Body	Remote Function Actuation																																																										
T	2008	ALL	Body	Passenger Presence System																																																										
T	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India										V																																																
T	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module										V																																																
T	2009	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
T	2009	ALL	Powertrain	Transmission Control Module																																																										
T	2009	ALL	Powertrain	Transmission Control Module																																																										
T	2009	ALL	Chassis	Electronic Brake Control Module																																																										
T	2009	ALL	Chassis	Tire Pressure Monitor																																																										
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2009	ALL	Body	Instrument Panel Cluster																																																										
T	2009	ALL	Body	Passenger Presence System																																																										
T	2009	ALL	Body	Theft Deterrent Module																										V	V																																
T	2009	ALL	Body	Radio																																																										
T	2009	ALL	Body	Remote Function Actuation																																																										
T	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module										V																																																
T	2010	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2010	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
T	2010	ALL	Powertrain	Transmission Control Module																																																										
T	2010	ALL	Powertrain	Transmission Control Module																																																										
T	2010	ALL	Chassis	Electronic Brake Control Module																																																										
T	2010	ALL	Chassis	Tire Pressure Monitor																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Instrument Panel Cluster																																																										
T	2010	ALL	Body	Passenger Presence System																																																										
T	2010	ALL	Body	Theft Deterrent Module																										V	V																																
T	2010	ALL	Body	Radio																																																										
T	2010	ALL	Body	Remote Function Actuation																																																										
T	2011	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
T	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																																
T	2011	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2011	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																																
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module										V																																																
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module Argentia										V																																																
T	2011	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
T	2011	ALL	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																										
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2011	ALL	Chassis	Electronic Brake Control Module																																																										
T	2011	ALL	Chassis	Tire Pressure Monitor																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2011	ALL	Body	Instrument Panel Cluster																																																									
T	2011	ALL	Body	Passenger Presence System																																																									
T	2011	ALL	Body	Theft Deterrent Module																										V	V																														
T	2011	ALL	Body	Radio																																																									
T	2011	ALL	Body	Remote Function Actuation																																																									
T	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																									
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
T	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																															
T	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																									
T	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																															
T	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module										V																																															
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																									
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
T	2012	Aveo	Powertrain	Fuel Injector Control Module																																																									
T	2012	Aveo	Powertrain	Fuel Pump Control Module																																																									
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2012	Aveo	Chassis	Electric Power Steering Control Module																																																									
T	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2012	Aveo	Chassis	Tire Pressure Monitor																																																									
T	2012	Aveo	Body	Body Control Module Hatchback																																																									
T	2012	Aveo	Body	Body Control Module Sedan																																																									
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2012	Aveo	Body	Passenger Presence Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2012	Aveo	Body	Instrument Cluster																																																										
T	2012	Aveo	Body	Radio																																																										
T	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																											
T	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
T	2012	Aveo	Body	Front Seat Heating Control Module																																																											
T	2012	Aveo	Body	Remote Function Actuation																																																											
T	2012	Aveo	Body	Parking Assist Control Module																																																											
T	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																											
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
T	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module										V																																																
T	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																											
T	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module										V																																																
T	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module										V																																																
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
T	2013	Aveo	Powertrain	Fuel Injector Control Module																																																											
T	2013	Aveo	Powertrain	Fuel Pump Control Module																																																											
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2013	Aveo	Chassis	Electric Power Steering Control Module																																																											
T	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2013	Aveo	Body	Body Control Module Hatchback																																																											
T	2013	Aveo	Body	Body Control Module Sedan																																																											
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	Aveo	Body	Passenger Presence Module																																																											
T	2013	Aveo	Body	Instrument Cluster																																																											
T	2013	Aveo	Body	Radio																																																											
T	2013	Aveo	Body	Telematics Communication Interface Control Module																																																											
T	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2013	Aveo	Body	Front Seat Heating Control Module																																																										
T	2013	Aveo	Body	Remote Function Actuation																																																										
T	2013	Aveo	Body	Parking Assist Control Module																																																										
T	2014	Aveo	Powertrain	1.2L LMU Engine Control Module										V																																																
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
T	2014	Aveo	Powertrain	1.4L L95 Engine Control Module										V																																																	
T	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																											
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																											
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																											
T	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																											
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
T	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																											
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
T	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
T	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
T	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
T	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module										V																																																	
T	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																											
T	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module										V																																																	
T	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
T	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
T	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
T	2014	Aveo	Powertrain	Chassis Control Module																																																											
T	2014	Aveo	Powertrain	Fuel Injector Control Module																																																											
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2014	Aveo	Chassis	Power Steering Control Module																																																											
T	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2014	Aveo	Body	Body Control Module Hatchback																																																											
T	2014	Aveo	Body	Body Control Module Sedan																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Aveo	Body	Instrument Cluster																																																										
T	2014	Aveo	Body	Radio																																																										
T	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2014	Aveo	Body	Front Seat Heating Control Module																																																										
T	2014	Aveo	Body	Keyless Entry Control Module						V																																																				
T	2014	Aveo	Body	Parking Assist Control Module																																																										
T	2015	Aveo	Powertrain	1.2L LMU Engine Control Module										V																																																
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L L95 Engine Control Module										V																																																
T	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module										V																																																
T	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
T	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module										V																																																
T	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
T	2015	Aveo	Powertrain	Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2015	Aveo	Powertrain	Fuel Injector Control Module																																																										
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2015	Aveo	Chassis	Power Steering Control Module																																																										
T	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2015	Aveo	Body	Body Control Module Hatchback																																																										
T	2015	Aveo	Body	Body Control Module Sedan																																																										
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Aveo	Body	Instrument Cluster																																																										
T	2015	Aveo	Body	Radio																																																										
T	2015	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2015	Aveo	Body	Front Seat Heating Control Module																																																										
T	2015	Aveo	Body	Keyless Entry Control Module						V																																																				
T	2015	Aveo	Body	Parking Assist Control Module																																																										
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.4L L95 Engine Control Module										V																																															
T	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module										V																																															
T	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
T	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module										V																																															
T	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
T	2016	Aveo	Powertrain	Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2016	Aveo	Chassis	Power Steering Control Module																																																										
T	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2016	Aveo	Body	Body Control Module Hatchback																																																										
T	2016	Aveo	Body	Body Control Module Sedan																																																										
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Aveo	Body	Instrument Cluster																																																										
T	2016	Aveo	Body	Radio																																																										
T	2016	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2016	Aveo	Body	Front Seat Heating Control Module																																																										
T	2016	Aveo	Body	Parking Assist Control Module																																																										
T	2016	Aveo	Body	Keyless Entry Control Module						V																																																				
T	2016	Aveo	Body	Frontview Camera Module																																																										
U	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
U	2004	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																										
U	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
U	2004	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
U	2004	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
U	2004	ALL	Chassis	Electronic Brake Control Module																																																										
U	2004	ALL	Chassis	Electronic Brake Control Module																																																										
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2004	ALL	Body	Remote Function Actuation																																																										
U	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
U	2005	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																										
U	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
U	2005	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
U	2005	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
U	2005	ALL	Chassis	Electronic Brake Control Module																																																										
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2005	ALL	Body	Remote Function Actuation																																																										
U	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
U	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
U	2006	ALL	Powertrain	Transmission Control Module																																																										
U	2006	ALL	Chassis	Electronic Brake Control Module																																																										
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2006	ALL	Body	Remote Function Actuation																																																										
U	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
U	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																															
U	2007	ALL	Powertrain	Transmission Control Module																																																										
U	2007	ALL	Chassis	Electronic Brake Control Module																																																										
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
U	2007	ALL	Body	Remote Function Actuation																																																										
U	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
U	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																																
U	2008	ALL	Powertrain	Transmission Control Module																																																											
U	2008	ALL	Chassis	Electronic Brake Control Module																																																											
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2008	ALL	Body	Remote Function Actuation																																																											
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																																
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																																
U	2010	Sail	Powertrain	1.4L LCU Engine Control Module										V																																																
U	2010	Sail	Powertrain	Transmission Control Module																																																											
U	2010	Sail	Chassis	Electronic Brake Control Module																																																											
U	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission										V																																																
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission										V																																																
U	2011	Sail	Powertrain	1.4L LCU Engine Control Module										V																																																
U	2011	Sail	Powertrain	Transmission Control Module																																																											
U	2011	Sail	Chassis	Electronic Brake Control Module																																																											
U	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission										V																																																
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission										V																																																
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission										V																																																
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission										V																																																
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																																
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																																
U	2012	Sail	Powertrain	Transmission Control Module																																																											
U	2012	Sail	Chassis	Electronic Brake Control Module																																																											
U	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																																
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																																
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																																
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																																
U	2013	Sail	Powertrain	Transmission Control Module																																																											
U	2013	Sail	Chassis	Electronic Brake Control Module																																																											
U	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																																
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																																
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																																
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																																
U	2014	Sail	Powertrain	Transmission Control Module																																																											
U	2014	Sail	Chassis	Electronic Brake Control Module																																																											
U	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																																

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																																
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
U	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																										
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																																
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																																
U	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																										
U	2015	Sail	Powertrain	Transmission Control Module																																																										
U	2015	Sail	Chassis	Electronic Brake Control Module																																																										
U	2015	Sail	Chassis	Electronic Brake Control Module																																																										
U	2015	Sail	Chassis	Power Steering Control Module																																																										
U	2015	Sail	Body	Body Control Module																																																										
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
U	2015	Sail	Body	Radio/HVAC Control																																																										
U	2015	Sail	Body	HVAC Control Module																																																										
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission										V																																																
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission										V																																																
U	2016	Sail	Powertrain	1.2L LMU Transmission Control Module																																																										
U	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																										
U	2016	Sail	Powertrain	1.3L LDV Transmission Control Module																																																										
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission										V																																																
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission										V																																																
U	2016	Sail	Powertrain	1.4L LCU Transmission Control Module																																																										
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
U	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																										
U	2016	Sail	Chassis	Electronic Brake Control Module																																																										
U	2016	Sail	Chassis	Electronic Brake Control Module																																																										
U	2016	Sail	Chassis	Power Steering Control Module																																																										
U	2016	Sail	Body	Body Control Module																																																										
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
U	2016	Sail	Body	Radio/HVAC Control																																																										
U	2016	Sail	Body	Radio																																																										
U	2016	Sail	Body	HVAC Control Module																																																										
V	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																																
V	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2004	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																										
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																										
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2004	ALL	Body	ISU																																																									
V	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																																
V	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2005	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
V	2005	ALL	Chassis	Electronic Brake Control Module																																																										
V	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2005	ALL	Body	ISU																																																									
V	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module										V																																																
V	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
V	2006	ALL	Powertrain	Transmission Control Module 4 Speed																																																								
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																								
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																								
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2006	ALL	Body	ISU																																																								
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																								
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector Control Module																																																								
V	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module										V																																														
V	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module										V																																														
V	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																								
V	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
V	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																								
V	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
V	2007	ALL	Chassis	Electronic Brake Control Module																																																								
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2007	ALL	Body	ISU																																																								
V	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																								
V	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
V	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
V	2008	ALL	Chassis	Electronic Brake Control Module																																																								
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2008	ALL	Body	ISU																																																								
V	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																								
V	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
V	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
V	2009	ALL	Chassis	Electronic Brake Control Module																																																								
V	2009	ALL	Body	ISU																																																								
V	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module										V																																														
V	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																								
V	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
V	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
V	2010	ALL	Chassis	Electronic Brake Control Module																																																								
V	2010	ALL	Body	ISU																																																								
V	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module										V																																														
V	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																								
V	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
V	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
V	2011	ALL	Chassis	Electronic Brake Control Module																																																								
V	2011	ALL	Body	ISU																																																								
W	2004	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module										V																																														
W	2004	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module										V																																														
W	2004	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module										V																																														
W	2004	ALL	Powertrain	Transmission Control Module											V																																													
W	2004	ALL	Body	Body Control Module												V	V																																											
W	2004	ALL	Body	Digital Radio Receiver																																																								
W	2004	ALL	Body	Driver Information Center																																																								
W	2004	ALL	Body	Heating and Air Conditioning																																																								
W	2004	ALL	Body	Instrument Panel Cluster																																																								
W	2004	ALL	Body	Personalization																																																								
W	2004	ALL	Body	Radio																		V	V																																					

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
W	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module										V																																																
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module										V																																																
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module										V																																																
W	2005	ALL	Powertrain	Transmission Control Module											V																																															
W	2005	ALL	Body	Body Control Module												V	V																																												
W	2005	ALL	Body	Digital Radio Receiver																																																										
W	2005	ALL	Body	Driver Information Center																																																										
W	2005	ALL	Body	Heating and Air Conditioning																																																										
W	2005	ALL	Body	Instrument Panel Cluster																																																										
W	2005	ALL	Body	Personalization																																																										
W	2005	ALL	Body	Radio																	V	V																																								
W	2005	ALL	Body	Supplemental Inflatable Restraint												V	V																																													
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																											
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																											
W	2006	ALL	Powertrain	Transmission Control Module																																																											
W	2006	ALL	Chassis	Anti-lock Brake System																																																											
W	2006	ALL	Body	Digital Radio Receiver																																																											
W	2006	ALL	Body	Radio																																																										
W	2006	ALL	Body	Instrument Panel Cluster																																																										
W	2006	ALL	Body	Seat																																																										
W	2006	ALL	Body	Theft Deterrent Module																										V	V																																
W	2006	ALL	Body	Body Control Module																																																										
W	2006	ALL	Body	HVAC C67 Single																																																											
W	2006	ALL	Body	HVAC CJ3 Dual																																																											
W	2006	ALL	Body	Remote Control Door Lock Receiver																																																											
W	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
W	2006	ALL	Body	Passenger Presence System																																																											
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																											
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module																																																											
W	2007	ALL	Powertrain	Transmission Control Module																																																											
W	2007	ALL	Chassis	Electronic Brake Control Module																																																											
W	2007	ALL	Body	Body Control Module																																																										
W	2007	ALL	Body	Digital Radio Receiver																																																											
W	2007	ALL	Body	Heated Seat Module																																																											
W	2007	ALL	Body	HVAC C67 Single																																																											
W	2007	ALL	Body	HVAC CJ3 Dual																																																											
W	2007	ALL	Body	Instrument Panel Cluster																																																											
W	2007	ALL	Body	Passenger Presence System																																																											
W	2007	ALL	Body	Radio																																																											
W	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
W	2007	ALL	Body	Theft Deterrent Module																										V	V																																
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module																																																											
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																											
W	2008	ALL	Powertrain	Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
W	2008	ALL	Chassis	Electronic Brake Control Module																																																										
W	2008	ALL	Body	Body Control Module																																																										
W	2008	ALL	Body	Digital Radio Receiver																																																										
W	2008	ALL	Body	Heated Seat Module																																																										
W	2008	ALL	Body	HVAC C67 Single																																																										
W	2008	ALL	Body	HVAC CJ3 Dual																																																										
W	2008	ALL	Body	Instrument Panel Cluster																																																										
W	2008	ALL	Body	Passenger Presence System																																																										
W	2008	ALL	Body	Radio																																																										
W	2008	ALL	Body	Remote Control Door Lock Receiver																								V	V																																		
W	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2008	ALL	Body	Theft Deterrent Module																										V	V																															
W	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
W	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
W	2009	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																										
W	2009	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																										
W	2009	ALL	Powertrain	Transmission Control Module																																																										
W	2009	ALL	Chassis	Electronic Brake Control Module																																																										
W	2009	ALL	Body	Body Control Module																																																										
W	2009	ALL	Body	Digital Radio Receiver																																																										
W	2009	ALL	Body	Heated Seat Module																																																										
W	2009	ALL	Body	HVAC C67 Single																																																										
W	2009	ALL	Body	HVAC CJ3 Dual																																																										
W	2009	ALL	Body	Instrument Panel Cluster																																																										
W	2009	ALL	Body	Passenger Presence System																																																										
W	2009	ALL	Body	Radio																																																										
W	2009	ALL	Body	Remote Control Door Lock Receiver																								V	V																																		
W	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2009	ALL	Body	Theft Deterrent Module																										V	V																															
W	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
W	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
W	2010	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																										
W	2010	ALL	Powertrain	Transmission Control Module																																																										
W	2010	ALL	Chassis	Electronic Brake Control Module																																																										
W	2010	ALL	Body	Body Control Module																																																										
W	2010	ALL	Body	Digital Radio Receiver																																																										
W	2010	ALL	Body	Heated Seat Module																																																										
W	2010	ALL	Body	HVAC C67 Single																																																										
W	2010	ALL	Body	HVAC CJ3 Dual																																																										
W	2010	ALL	Body	Instrument Panel Cluster																																																										
W	2010	ALL	Body	Passenger Presence System																																																										
W	2010	ALL	Body	Radio																																																										
W	2010	ALL	Body	Remote Control Door Lock Receiver																								V	V																																		
W	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2010	ALL	Body	Theft Deterrent Module																										V	V																															
W	2011	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
W	2011	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																										
W	2011	ALL	Powertrain	Transmission Control Module																																																										
W	2011	ALL	Chassis	Electronic Brake Control Module																																																										
W	2011	ALL	Body	Body Control Module																																																										
W	2011	ALL	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
W	2011	ALL	Body	Heated Seat Module																																																										
W	2011	ALL	Body	HVAC C67 Single																																																										
W	2011	ALL	Body	HVAC CJ3 Dual																																																										
W	2011	ALL	Body	Instrument Panel Cluster																																																										
W	2011	ALL	Body	Passenger Presence System																																																										
W	2011	ALL	Body	Radio																																																										
W	2011	ALL	Body	Remote Control Door Lock Receiver																							V	V																																			
W	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2011	ALL	Body	Theft Deterrent Module																									V	V																																
W	2012	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
W	2012	ALL	Powertrain	Transmission Control Module																																																										
W	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
W	2012	ALL	Chassis	Electronic Brake Control Module																																																										
W	2012	ALL	Body	Body Control Module																																																										
W	2012	ALL	Body	Digital Radio Receiver																																																										
W	2012	ALL	Body	Heated Seat Module																																																										
W	2012	ALL	Body	HVAC C67 Single																																																										
W	2012	ALL	Body	HVAC CJ3 Dual																																																										
W	2012	ALL	Body	Instrument Panel Cluster																																																										
W	2012	ALL	Body	Passenger Presence System																																																										
W	2012	ALL	Body	Radio																																																										
W	2012	ALL	Body	Remote Control Door Lock Receiver																							V	V																																			
W	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2012	ALL	Body	Theft Deterrent Module																									V	V																																
W	2013	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
W	2013	ALL	Powertrain	Transmission Control Module																																																										
W	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
W	2013	ALL	Chassis	Electronic Brake Control Module																																																										
W	2013	ALL	Body	Body Control Module																																																										
W	2013	ALL	Body	Digital Radio Receiver																																																										
W	2013	ALL	Body	Heated Seat Module																																																										
W	2013	ALL	Body	HVAC C67 Single																																																										
W	2013	ALL	Body	HVAC CJ3 Dual																																																										
W	2013	ALL	Body	Instrument Panel Cluster																																																										
W	2013	ALL	Body	Passenger Presence System																																																										
W	2013	ALL	Body	Radio																																																										
W	2013	ALL	Body	Remote Control Door Lock Receiver																							V	V																																			
W	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2013	ALL	Body	Theft Deterrent Module																									V	V																																
W	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
W	2014	Impala	Chassis	Electronic Brake Control Module																																																										
W	2014	Impala	Body	Body Control Module																																																										
W	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2014	Impala	Body	Passenger Presence Module																																																										
W	2014	Impala	Body	Instrument Cluster																																																										
W	2014	Impala	Body	Radio																																																										
W	2014	Impala	Body	Digital Radio Receiver Control Module																																																										
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																										
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
W	2014	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
W	2014	Impala	Body	HVAC Manual Control Single Zone (C67)																																																											
W	2014	Impala	Body	Front Seat Heating Control Module																																																											
W	2014	Impala	Body	Remote Control Door Lock Receiver																																																											
W	2014	Impala	Body	Theft Deterrent Module				V	V																																																						
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																											
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																											
W	2014	Lumina	Powertrain	(2) 6.0L L77 Transmission Control Module																																																											
W	2014	Lumina	Powertrain	Fuel Injector Control Module																																																											
W	2014	Lumina	Powertrain	Chassis Control Module																																																											
W	2014	Lumina	Chassis	Electronic Brake Control Module																																																											
W	2014	Lumina	Chassis	Parking Brake Control Module																																																											
W	2014	Lumina	Chassis	Power Steering Control Module																																																											
W	2014	Lumina	Chassis	Steering Wheel Angle Sensor Module																																																											
W	2014	Lumina	Chassis	Suspension Control Module																																																											
W	2014	Lumina	Body	Body Control Module Coupe																																																											
W	2014	Lumina	Body	Body Control Module Sedan																																																											
W	2014	Lumina	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
W	2014	Lumina	Body	Instrument Cluster																																																											
W	2014	Lumina	Body	Head-Up Display Module																																																											
W	2014	Lumina	Body	Radio Control																																																											
W	2014	Lumina	Body	HVAC Control																																																											
W	2014	Lumina	Body	Headlamp Control Module																																																											
W	2014	Lumina	Body	Trailer Interface Control Module																																																											
W	2014	Lumina	Body	Radio																																																											
W	2014	Lumina	Body	HVAC Control Module																																																											
W	2014	Lumina	Body	Keyless Entry Control Module																																																											
W	2014	Lumina	Body	Right Side Object Detection Control Module																																																											
W	2014	Lumina	Body	Left Side Object Detection Control Module																																																											
W	2014	Lumina	Body	Parking Assist Control Module																																																											
W	2014	Lumina	Body	Frontview Camera Module																																																											
W	2014	Lumina	Body	Steering Column Lock Control Module																																																											
W	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
W	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
W	2015	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																											
W	2015	Impala	Chassis	Electronic Brake Control Module																																																											
W	2015	Impala	Body	Body Control Module																																																											
W	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
W	2015	Impala	Body	Passenger Presence Module																																																											
W	2015	Impala	Body	Instrument Cluster																																																											
W	2015	Impala	Body	Radio																																																											
W	2015	Impala	Body	Digital Radio Receiver Control Module																																																											
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 9																																																											
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 10																																																											
W	2015	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
W	2015	Impala	Body	HVAC Manual Control Single Zone (C67)																																																											
W	2015	Impala	Body	Front Seat Heating Control Module																																																											
W	2015	Impala	Body	Remote Control Door Lock Receiver																																																											
W	2015	Impala	Body	Theft Deterrent Module				V	V																																																						
W	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
W	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
W	2016	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
W	2016	Impala	Chassis	Electronic Brake Control Module																																																											
W	2016	Impala	Body	Body Control Module																																																										
W	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
W	2016	Impala	Body	Passenger Presence Module																																																											
W	2016	Impala	Body	Instrument Cluster																																																											
W	2016	Impala	Body	Radio																																																											
W	2016	Impala	Body	Digital Radio Receiver Control Module																																																											
W	2016	Impala	Body	Telematics Communication Interface Control Module																																																											
W	2016	Impala	Body	HVAC Manual Control Dual Zone (CJ2)																																																											
W	2016	Impala	Body	HVAC Manual Control Single Zone (C67)																																																											
W	2016	Impala	Body	Front Seat Heating Control Module																																																											
W	2016	Impala	Body	Remote Control Door Lock Receiver																																																											
W	2016	Impala	Body	Theft Deterrent Module				V	V																																																						
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Auto																																																											
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Manual																																																											
Y	2004	ALL	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																											
Y	2004	ALL	Powertrain	Transmission Control Module																																																											
Y	2004	ALL	Chassis	RTD																																																										
Y	2004	ALL	Body	Body Control Module												V	V																																												
Y	2004	ALL	Body	Heating and Air Conditioning												V	V																																													
Y	2004	ALL	Body	Instrument Panel Cluster												V	V																																													
Y	2004	ALL	Body	Left Door Control Module																																																										
Y	2004	ALL	Body	Radio												V	V																																												
Y	2004	ALL	Body	Remote Function Actuation																																																										
Y	2004	ALL	Body	Right Door Control Module																																																										
Y	2004	ALL	Body	Seat Control Module																																																										
Y	2004	ALL	Body	Supplemental Inflatable Restraint												V	V																																												
Y	2005	ALL	Powertrain	Engine Control Module																																																										
Y	2005	ALL	Powertrain	Transmission Control Module																																																										
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2005	ALL	Chassis	Electronic Suspension Control																																																										
Y	2005	ALL	Chassis	Steering Wheel and Column																																																										
Y	2005	ALL	Body	Amplifier																																																										
Y	2005	ALL	Body	Body Control Module																																																										
Y	2005	ALL	Body	Digital Radio Receiver																																																										
Y	2005	ALL	Body	Driver Door Module																																																										
Y	2005	ALL	Body	Driver Door Switch																																																										
Y	2005	ALL	Body	Driver Position Module																																																										
Y	2005	ALL	Body	Folding Top Module																																																										
Y	2005	ALL	Body	Head Up Display																																																										
Y	2005	ALL	Body	HVAC Control Module																																																										
Y	2005	ALL	Body	Instrument Panel Cluster																																																										
Y	2005	ALL	Body	Navigation Radio																																																										
Y	2005	ALL	Body	Passenger Door Module																																																										
Y	2005	ALL	Body	Radio																																																										
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2006	ALL	Powertrain	Engine Control Module																																																										
Y	2006	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2006	ALL	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Y	2006	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2006	ALL	Chassis	Electronic Suspension Control																																																										
Y	2006	ALL	Chassis	Steering Wheel and Column																																																										
Y	2006	ALL	Body	Body Control Module																																																									
Y	2006	ALL	Body	CD Changer																																																									
Y	2006	ALL	Body	Digital Radio Receiver																																																									
Y	2006	ALL	Body	Driver Door Module																																																									
Y	2006	ALL	Body	Driver Door Switch																																																									
Y	2006	ALL	Body	Driver Position Module																																																									
Y	2006	ALL	Body	Folding Top Module																																																									
Y	2006	ALL	Body	Head Up Display																																																									
Y	2006	ALL	Body	HVAC Control Module																																																									
Y	2006	ALL	Body	Instrument Panel Cluster																																																										
Y	2006	ALL	Body	Navigation Radio																																																									
Y	2006	ALL	Body	Passenger Door Module																																																									
Y	2006	ALL	Body	Radio																																																									
Y	2006	ALL	Body	Remote Control Door Lock Receiver																																																									
Y	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2007	ALL	Powertrain	Engine Control Module																																																									
Y	2007	ALL	Powertrain	Exhaust Flow Control Module																																																									
Y	2007	ALL	Powertrain	Transmission Control Module																																																									
Y	2007	ALL	Chassis	Electronic Brake Control Module																																																									
Y	2007	ALL	Chassis	Electronic Suspension Control																																																									
Y	2007	ALL	Body	Body Control Module																																																									
Y	2007	ALL	Body	CD Changer																																																									
Y	2007	ALL	Body	Digital Radio Receiver																																																									
Y	2007	ALL	Body	Driver Door Module																																																									
Y	2007	ALL	Body	Driver Door Switch																																																									
Y	2007	ALL	Body	Driver Position Module																																																									
Y	2007	ALL	Body	Folding Top Module																																																									
Y	2007	ALL	Body	Head Up Display																																																									
Y	2007	ALL	Body	HVAC Control Module																																																									
Y	2007	ALL	Body	Instrument Panel Cluster																																																										
Y	2007	ALL	Body	Navigation Radio																																																									
Y	2007	ALL	Body	Passenger Door Module																																																									
Y	2007	ALL	Body	Radio																																																									
Y	2007	ALL	Body	Remote Control Door Lock Receiver																																																									
Y	2007	ALL	Body	Steering Column Lock Module																																																									
Y	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2008	ALL	Powertrain	Engine Control Module																																																									
Y	2008	ALL	Powertrain	Exhaust Flow Control Module																																																									
Y	2008	ALL	Powertrain	Transmission Control Module																																																									
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																									
Y	2008	ALL	Chassis	Electronic Suspension Control																																																									
Y	2008	ALL	Body	Body Control Module																																																									
Y	2008	ALL	Body	CD Changer																																																									
Y	2008	ALL	Body	Digital Radio Receiver																																																									
Y	2008	ALL	Body	Driver Door Module																																																									
Y	2008	ALL	Body	Driver Door Switch																																																									
Y	2008	ALL	Body	Driver Position Module																																																									
Y	2008	ALL	Body	Folding Top Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Y	2008	ALL	Body	Head Up Display																																																										
Y	2008	ALL	Body	HVAC Control Module																																																										
Y	2008	ALL	Body	Instrument Panel Cluster																																																										
Y	2008	ALL	Body	Navigation Radio																																																										
Y	2008	ALL	Body	Passenger Door Module																																																										
Y	2008	ALL	Body	Radio																																																										
Y	2008	ALL	Body	Personal Audio Link Module																																																										
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2008	ALL	Body	Steering Column Lock Module																																																										
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																										
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																										
Y	2009	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2009	ALL	Chassis	Electronic Suspension Control																																																										
Y	2009	ALL	Body	Body Control Module																																																										
Y	2009	ALL	Body	CD Changer																																																										
Y	2009	ALL	Body	Digital Radio Receiver																																																										
Y	2009	ALL	Body	Driver Door Module																																																										
Y	2009	ALL	Body	Driver Door Switch																																																										
Y	2009	ALL	Body	Driver Position Module																																																										
Y	2009	ALL	Body	Folding Top Module																																																										
Y	2009	ALL	Body	Head Up Display																																																										
Y	2009	ALL	Body	HVAC Control Module																																																										
Y	2009	ALL	Body	Instrument Panel Cluster																																																										
Y	2009	ALL	Body	Navigation Radio																																																										
Y	2009	ALL	Body	Passenger Door Module																																																										
Y	2009	ALL	Body	Radio																																																										
Y	2009	ALL	Body	Personal Audio Link Module																																																										
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2009	ALL	Body	Steering Column Lock Module																																																										
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																										
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																										
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																										
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																										
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2010	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2010	ALL	Chassis	Electronic Suspension Control																																																										
Y	2010	ALL	Body	Body Control Module																																																										
Y	2010	ALL	Body	CD Changer																																																										
Y	2010	ALL	Body	Digital Radio Receiver																																																										
Y	2010	ALL	Body	Driver Door Module																																																										
Y	2010	ALL	Body	Driver Door Switch																																																										
Y	2010	ALL	Body	Driver Position Module																																																										
Y	2010	ALL	Body	Folding Top Module																																																										
Y	2010	ALL	Body	Head Up Display																																																										
Y	2010	ALL	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Y	2010	ALL	Body	Instrument Panel Cluster																																																										
Y	2010	ALL	Body	Navigation Radio																																																										
Y	2010	ALL	Body	Passenger Door Module																																																										
Y	2010	ALL	Body	Radio																																																										
Y	2010	ALL	Body	Personal Audio Link Module																																																										
Y	2010	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2010	ALL	Body	Steering Column Lock Module																																																										
Y	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																										
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																										
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																										
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																										
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2011	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2011	ALL	Chassis	Electronic Suspension Control																																																										
Y	2011	ALL	Body	Body Control Module																																																									
Y	2011	ALL	Body	CD Changer																																																									
Y	2011	ALL	Body	Digital Radio Receiver																																																									
Y	2011	ALL	Body	Driver Door Module																																																									
Y	2011	ALL	Body	Driver Door Switch																																																									
Y	2011	ALL	Body	Driver Position Module																																																									
Y	2011	ALL	Body	Folding Top Module																																																									
Y	2011	ALL	Body	Head Up Display																																																									
Y	2011	ALL	Body	HVAC Control Module																																																									
Y	2011	ALL	Body	Instrument Panel Cluster																																																									
Y	2011	ALL	Body	Navigation Radio																																																									
Y	2011	ALL	Body	Passenger Door Module																																																									
Y	2011	ALL	Body	Radio																																																									
Y	2011	ALL	Body	Personal Audio Link Module																																																									
Y	2011	ALL	Body	Remote Control Door Lock Receiver																																																									
Y	2011	ALL	Body	Steering Column Lock Module																																																									
Y	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																									
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																									
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																									
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																									
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																									
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																									
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																									
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																									
Y	2012	ALL	Chassis	Electronic Brake Control Module																																																									
Y	2012	ALL	Chassis	Electronic Suspension Control																																																									
Y	2012	ALL	Body	Body Control Module																																																								
Y	2012	ALL	Body	CD Changer																																																								
Y	2012	ALL	Body	Digital Radio Receiver																																																								
Y	2012	ALL	Body	Driver Door Module																																																								
Y	2012	ALL	Body	Driver Door Switch																																																								
Y	2012	ALL	Body	Driver Position Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Y	2012	ALL	Body	Folding Top Module																																																									
Y	2012	ALL	Body	Head Up Display																																																									
Y	2012	ALL	Body	HVAC Control Module																																																									
Y	2012	ALL	Body	Instrument Panel Cluster																																																									
Y	2012	ALL	Body	Navigation Radio																																																									
Y	2012	ALL	Body	Passenger Door Module																																																									
Y	2012	ALL	Body	Radio																																																									
Y	2012	ALL	Body	Personal Audio Link Module																																																									
Y	2012	ALL	Body	Remote Control Door Lock Receiver																																																									
Y	2012	ALL	Body	Steering Column Lock Module																																																									
Y	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																									
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																									
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																									
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																									
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																									
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																									
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																									
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																									
Y	2013	ALL	Chassis	Electronic Brake Control Module																																																									
Y	2013	ALL	Chassis	Electronic Suspension Control																																																									
Y	2013	ALL	Body	Body Control Module																																																								
Y	2013	ALL	Body	CD Changer																																																								
Y	2013	ALL	Body	Digital Radio Receiver																																																								
Y	2013	ALL	Body	Driver Door Module																																																								
Y	2013	ALL	Body	Driver Door Switch																																																								
Y	2013	ALL	Body	Driver Position Module																																																								
Y	2013	ALL	Body	Folding Top Module																																																								
Y	2013	ALL	Body	Head Up Display																																																								
Y	2013	ALL	Body	HVAC Control Module																																																								
Y	2013	ALL	Body	Instrument Panel Cluster																																																								
Y	2013	ALL	Body	Navigation Radio																																																								
Y	2013	ALL	Body	Passenger Door Module																																																								
Y	2013	ALL	Body	Radio																																																								
Y	2013	ALL	Body	Personal Audio Link Module																																																								
Y	2013	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2013	ALL	Body	Steering Column Lock Module																																																								
Y	2013	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																								
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																								
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																								
Y	2014	Corvette	Powertrain	Chassis Control Module																																																								
Y	2014	Corvette	Chassis	Electronic Brake Control Module																																																								
Y	2014	Corvette	Chassis	Parking Brake Control Module																																																								
Y	2014	Corvette	Chassis	Power Steering Control Module																																																								
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																								
Y	2014	Corvette	Chassis	Suspension Control Module																																																								
Y	2014	Corvette	Body	Body Control Module Convertible																																																								
Y	2014	Corvette	Body	Body Control Module Coupe																																																								
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
Y	2014	Corvette	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Y	2014	Corvette	Body	Instrument Cluster																																																										
Y	2014	Corvette	Body	Radio/HVAC Control																																																										
Y	2014	Corvette	Body	Inside Rearview Mirror																																																										
Y	2014	Corvette	Body	Radio																																																										
Y	2014	Corvette	Body	Amplifier																																																										
Y	2014	Corvette	Body	Human Machine Interface Control Module																																																										
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2014	Corvette	Body	HVAC Control Module																																																										
Y	2014	Corvette	Body	Seat Memory Control Module - Passenger																																																										
Y	2014	Corvette	Body	Seat Memory Control Module - Driver	V																																																									
Y	2014	Corvette	Body	Folding Top Control Module																																																										
Y	2014	Corvette	Body	Keyless Entry Control Module																																																										
Y	2014	Corvette	Body	Steering Column Lock Control Module																																																										
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																										
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																										
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																										
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Automatic Transmission																																																										
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Manual Transmission																																																										
Y	2015	Corvette	Powertrain	6.2L LT4 Transmission Control Module																																																										
Y	2015	Corvette	Powertrain	Chassis Control Module																																																										
Y	2015	Corvette	Chassis	Electronic Brake Control Module																																																										
Y	2015	Corvette	Chassis	Parking Brake Control Module																																																										
Y	2015	Corvette	Chassis	Power Steering Control Module																																																										
Y	2015	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																										
Y	2015	Corvette	Chassis	Suspension Control Module																																																										
Y	2015	Corvette	Body	Body Control Module Convertible																																																										
Y	2015	Corvette	Body	Body Control Module Coupe																																																										
Y	2015	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Y	2015	Corvette	Body	Passenger Presence Module																																																										
Y	2015	Corvette	Body	Instrument Cluster																																																										
Y	2015	Corvette	Body	Radio/HVAC Control																																																										
Y	2015	Corvette	Body	Vehicle Performance Data Recorder																																																										
Y	2015	Corvette	Body	Inside Rearview Mirror																																																										
Y	2015	Corvette	Body	Radio																																																										
Y	2015	Corvette	Body	Amplifier																																																										
Y	2015	Corvette	Body	Human Machine Interface Control Module																																																										
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2015	Corvette	Body	HVAC Control Module																																																										
Y	2015	Corvette	Body	Seat Memory Control Module - Passenger																																																										
Y	2015	Corvette	Body	Seat Memory Control Module - Driver																																																										
Y	2015	Corvette	Body	Folding Top Control Module																																																										
Y	2015	Corvette	Body	Keyless Entry Control Module																																																										
Y	2015	Corvette	Body	Steering Column Lock Control Module																																																										
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																										
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																										
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Automatic Transmission																																																										
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Manual Transmission																																																										
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Y	2016	Corvette	Powertrain	Rear Differential Clutch Control Module																																																									
Y	2016	Corvette	Chassis	Electronic Brake Control Module																																																									
Y	2016	Corvette	Chassis	Parking Brake Control Module																																																									
Y	2016	Corvette	Chassis	Power Steering Control Module																																																									
Y	2016	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																									
Y	2016	Corvette	Chassis	Suspension Control Module																																																									
Y	2016	Corvette	Body	Body Control Module																																																									
Y	2016	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
Y	2016	Corvette	Body	Passenger Presence Module																																																									
Y	2016	Corvette	Body	Instrument Cluster																																																									
Y	2016	Corvette	Body	Radio/HVAC Control																																																									
Y	2016	Corvette	Body	Vehicle Performance Data Recorder																																																									
Y	2016	Corvette	Body	Video Processing Control Module																																				V																					
Y	2016	Corvette	Body	Inside Rearview Mirror																																																									
Y	2016	Corvette	Body	Radio																																																									
Y	2016	Corvette	Body	Amplifier																																																									
Y	2016	Corvette	Body	Human Machine Interface Control Module																																																									
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																									
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																									
Y	2016	Corvette	Body	HVAC Control Module																																																									
Y	2016	Corvette	Body	Liftgate Control Module																																																									
Y	2016	Corvette	Body	Seat Memory Control Module - Passenger																																																									
Y	2016	Corvette	Body	Seat Memory Control Module - Driver																																																									
Y	2016	Corvette	Body	Folding Top Control Module																																																									
Y	2016	Corvette	Body	Keyless Entry Control Module																																																									
Y	2016	Corvette	Body	Steering Column Lock Control Module																																																									
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																									
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																									
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																									
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																									
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																									
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																									
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																									
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																									
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																									
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																									
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																									
Y	2016	Cruze	Chassis	Electronic Brake Control Module																																		V	V																					
Y	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																									
Y	2016	Cruze	Chassis	Power Steering Control Module																																																									
Y	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
Y	2016	Cruze	Body	Body Control Module																																																									
Y	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
Y	2016	Cruze	Body	Passenger Presence Module																																																									
Y	2016	Cruze	Body	Instrument Cluster																																																									
Y	2016	Cruze	Body	Radio Controls																																																									
Y	2016	Cruze	Body	HVAC Controls																																																									
Y	2016	Cruze	Body	Trailer Interface Control Module																																																									
Y	2016	Cruze	Body	Radio Base (IO3 IO7)																																																									
Y	2016	Cruze	Body	Radio (IOA)																																																									
Y	2016	Cruze	Body	Radio (IOB)																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Y	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																										
Y	2016	Cruze	Body	Amplifier																																																										
Y	2016	Cruze	Body	Multimedia Player Interface Module																																																										
Y	2016	Cruze	Body	Human Machine Interface Control Module																																																										
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
Y	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																										
Y	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																										
Y	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																										
Y	2016	Cruze	Body	Keyless Entry Control Module																																																										
Y	2016	Cruze	Body	Right Side Object Detection Control Module																																																										
Y	2016	Cruze	Body	Left Side Object Detection Control Module																																																										
Y	2016	Cruze	Body	Parking Assist Control Module																																																										
Y	2016	Cruze	Body	Frontview Camera Module																																																										
Y	2016	Cruze	Body	Steering Column Lock Control Module																																																										
Y	2016	Cruze	Body	Long Range Radar Sensor Module																																																										
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module										V																																															
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Transmission Control Module																																																										
Z	2004	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2004	ALL	Chassis	Power Steering Control Module																																																										
Z	2004	ALL	Body	Body Control Module																																																									
Z	2004	ALL	Body	Digital Radio Receiver																																																										
Z	2004	ALL	Body	HVAC Control Module																																																										
Z	2004	ALL	Body	Instrument Panel Cluster																																																										
Z	2004	ALL	Body	Radio																																																										
Z	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2004	ALL	Body	Theft Deterrent Module																											V																															
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2005	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module										V																																															
Z	2005	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2005	ALL	Chassis	Power Steering Control Module																																																										
Z	2005	ALL	Body	Body Control Module																																																									
Z	2005	ALL	Body	Digital Radio Receiver																																																										
Z	2005	ALL	Body	HVAC Control Module																																																										
Z	2005	ALL	Body	Instrument Panel Cluster																																																										
Z	2005	ALL	Body	Radio																																																										
Z	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2005	ALL	Body	Theft Deterrent Module																											V																															
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2006	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module										V																																															
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
Z	2006	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2006	ALL	Chassis	Power Steering Control Module																																																										
Z	2006	ALL	Body	Body Control Module																																																										
Z	2006	ALL	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Z	2006	ALL	Body	HVAC Control Module																																																									
Z	2006	ALL	Body	Instrument Panel Cluster																																																									
Z	2006	ALL	Body	Radio																																																									
Z	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
Z	2006	ALL	Body	Theft Deterrent Module																											V																														
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																						V																																			
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																									
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																									
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																									
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																									
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																									
Z	2007	ALL	Chassis	Electronic Brake Control Module																																																									
Z	2007	ALL	Chassis	Power Steering Control Module																																																									
Z	2007	ALL	Body	Body Control Module																																																									
Z	2007	ALL	Body	Digital Radio Receiver																																																									
Z	2007	ALL	Body	Disc Player and Video Display																																																									
Z	2007	ALL	Body	HVAC Control Module																																																									
Z	2007	ALL	Body	Instrument Panel Cluster																																																									
Z	2007	ALL	Body	Radio																																																									
Z	2007	ALL	Body	Remote Control Door Lock Receiver																								V	V																																
Z	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
Z	2007	ALL	Body	Theft Deterrent Module																											V																														
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																						V																																			
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																									
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																									
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																									
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																									
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																									
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																									
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																									
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
Z	2008	ALL	Chassis	Electronic Brake Control Module																																																									
Z	2008	ALL	Chassis	Power Steering Control Module																																																									
Z	2008	ALL	Body	Body Control Module Classic																																																									
Z	2008	ALL	Body	Body Control Module Malibu																																																									
Z	2008	ALL	Body	Digital Radio Receiver																																																									
Z	2008	ALL	Body	Disc Player and Video Display																																																									
Z	2008	ALL	Body	HVAC Control Module Classic																																																									
Z	2008	ALL	Body	HVAC Control Module Malibu																																																									
Z	2008	ALL	Body	Instrument Panel Cluster Classic																																																									
Z	2008	ALL	Body	Instrument Panel Cluster Malibu																																																									
Z	2008	ALL	Body	Radio																																																									
Z	2008	ALL	Body	Remote Control Door Lock Receiver																								V	V																																
Z	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
Z	2008	ALL	Body	Theft Deterrent Module																											V																														
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																						V																																			
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																									
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																									
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump																						V																																			
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump																																																									
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Without Tap Shift																																																										
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																										
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
Z	2009	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2009	ALL	Chassis	Power Steering Control Module																																																										
Z	2009	ALL	Body	Body Control Module																																																										
Z	2009	ALL	Body	Digital Radio Receiver																																																										
Z	2009	ALL	Body	Disc Player and Video Display																																																										
Z	2009	ALL	Body	HVAC Control Module																																																										
Z	2009	ALL	Body	Instrument Panel Cluster																																																										
Z	2009	ALL	Body	Personal Audio Link Module																																																										
Z	2009	ALL	Body	Radio																																																										
Z	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2009	ALL	Body	Theft Deterrent Module																											V																																
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																						V																																				
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																										
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																										
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Engine Control Module																						V																																				
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 6 Speed																																																										
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 4 Speed																																																										
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																						V																																				
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																										
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																										
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
Z	2010	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2010	ALL	Chassis	Power Steering Control Module																																																										
Z	2010	ALL	Body	Body Control Module																																																										
Z	2010	ALL	Body	Digital Radio Receiver																																																										
Z	2010	ALL	Body	HVAC Control Module																																																										
Z	2010	ALL	Body	Instrument Panel Cluster																																																										
Z	2010	ALL	Body	Personal Audio Link Module																																																										
Z	2010	ALL	Body	Radio																																																										
Z	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2010	ALL	Body	Theft Deterrent Module																											V																																
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																						V																																				
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Engine Control Module																						V																																				
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																										
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
Z	2011	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2011	ALL	Chassis	Power Steering Control Module																																																										
Z	2011	ALL	Body	Body Control Module																																																										
Z	2011	ALL	Body	Digital Radio Receiver																																																										
Z	2011	ALL	Body	HVAC Control Module																																																										
Z	2011	ALL	Body	Instrument Panel Cluster																																																										
Z	2011	ALL	Body	Personal Audio Link Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Z	2011	ALL	Body	Radio																																																										
Z	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2011	ALL	Body	Theft Deterrent Module																											V																															
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Engine Control Module																						V																																				
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Transmission Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Engine Control Module																						V																																				
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Engine Control Module																						V																																				
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Chassis	Electronic Brake Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Chassis	Power Steering Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Body	Body Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Body	Digital Radio Receiver																																																										
Z	2012	Malibu (Seventh Gen)	Body	HVAC Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Body	Instrument Panel Cluster																																																										
Z	2012	Malibu (Seventh Gen)	Body	Personal Audio Link Module																																																										
Z	2012	Malibu (Seventh Gen)	Body	Radio																																																										
Z	2012	Malibu (Seventh Gen)	Body	Supplemental Inflatable Restraint																																																										
Z	2012	Malibu (Seventh Gen)	Body	Theft Deterrent Module																											V																															
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Transmission Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Transmission Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Fuel Pump Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Transmission Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Fuel Pump Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	Rear Differential Clutch Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Chassis	Electronic Brake Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Chassis	Parking Brake Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
Z	2012	Malibu (Eighth Gen)	Chassis	Power Steering Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
Z	2012	Malibu (Eighth Gen)	Chassis	Suspension Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																										
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																										
Z	2012	Malibu (Eighth Gen)	Body	Passenger Presence Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Z	2012	Malibu (Eighth Gen)	Body	Instrument Cluster																																																										
Z	2012	Malibu (Eighth Gen)	Body	Head-Up Display Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Headlamp Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Radio																																																										
Z	2012	Malibu (Eighth Gen)	Body	Digital Radio Receiver Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Multimedia Player Interface Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Mobile Telephone Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Dual (CJ2)																																																										
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Single (C68)																																																										
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Manual Single (C67)																																																										
Z	2012	Malibu (Eighth Gen)	Body	Rear Seat Heating Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Keyless Entry Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Right Side Object Detection Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Left Side Object Detection Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Parking Assist Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Vehicle Direction Camera Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Steering Column Lock Control Module																																																										
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Engine Control Module																																																										
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Transmission Control Module																																																										
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Engine Control Module																																																										
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 1																																																										
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 2																																																										
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module																																																										
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 6 Speed (MNM)																																																										
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 8 Speed (MRC)																																																										
Z	2016	Malibu	Chassis	Electronic Brake Control Module																																		V	V																						
Z	2016	Malibu	Chassis	Brake Booster Control Module																																																										
Z	2016	Malibu	Chassis	Power Steering Control Module																																																										
Z	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
Z	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
Z	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Z	2016	Malibu	Body	Passenger Presence Module																																																										
Z	2016	Malibu	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
Z	2016	Malibu	Body	Instrument Cluster Enhanced Monochrome Driver Info Center (UDC)																																																										
Z	2016	Malibu	Body	Radio Controls																																																										
Z	2016	Malibu	Body	HVAC Controls																																																										
Z	2016	Malibu	Body	Active Safety Control Module																																																										
Z	2016	Malibu	Body	Headlamp Control Module																																																										
Z	2016	Malibu	Body	Radio Base																																																										
Z	2016	Malibu	Body	Radio (IOA)																																																										
Z	2016	Malibu	Body	Radio Uplevel (IO4 IO5 IO6)																																																										
Z	2016	Malibu	Body	Amplifier																																																										
Z	2016	Malibu	Body	Human Machine Interface Control Module																																																										
Z	2016	Malibu	Body	Navigation Control Module																																																										
Z	2016	Malibu	Body	Mobile Telephone Control Module																																																										
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																										
Z	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
Z	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
Z	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
Z	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Z	2016	Malibu	Body	Electric A/C Compressor Control Module																																																											
Z	2016	Malibu	Body	Seat Memory Control Module - Driver																																																											
Z	2016	Malibu	Body	Keyless Entry Control Module																																																											
Z	2016	Malibu	Body	Right Side Object Detection Control Module																																																											
Z	2016	Malibu	Body	Left Side Object Detection Control Module																																																											
Z	2016	Malibu	Body	Parking Assist Control Module																																																											
Z	2016	Malibu	Body	Frontview Camera Module																																																											
Z	2016	Malibu	Body	Frontview Camera Module																																																											
Z	2016	Malibu	Body	Steering Column Lock Control Module																																																											
Z	2016	Malibu	Body	Long Range Radar Sensor Module																																																											
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
1	2013	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
1	2013	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																											
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																											
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																											
1	2013	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																											
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Automatic Transmission																																																											
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Manual Transmission																																																											
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																											
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																											
1	2013	Malibu	Powertrain	2.0L LTD Fuel Pump Control Module																																																											
1	2013	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																											
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
1	2013	Malibu	Powertrain	(X) 2.0L LTG Fuel Pump Control Module																																																											
1	2013	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
1	2013	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																											
1	2013	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2013	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																											
1	2013	Malibu	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																											
1	2013	Malibu	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																																																											
1	2013	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
1	2013	Malibu	Powertrain	(A) 2.5L LCV Fuel Pump Control Module																																																											
1	2013	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
1	2013	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
1	2013	Malibu	Chassis	Electronic Brake Control Module																																																											
1	2013	Malibu	Chassis	Parking Brake Control Module																																																											
1	2013	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2013	Malibu	Chassis	Power Steering Control Module																																																											
1	2013	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2013	Malibu	Chassis	Suspension Control Module																																																											
1	2013	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2013	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																										
1	2013	Malibu	Body	Passenger Presence Module																																																											
1	2013	Malibu	Body	Instrument Cluster																																																											
1	2013	Malibu	Body	Headlamp Control Module																																																											
1	2013	Malibu	Body	Radio																																																											
1	2013	Malibu	Body	Digital Radio Receiver Control Module																																																											
1	2013	Malibu	Body	Multimedia Player Interface Module																																																											
1	2013	Malibu	Body	Mobile Telephone Control Module																																																											
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2013	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
1	2013	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											
1	2013	Malibu	Body	HVAC Control Module Manual Single (C67)																																																											
1	2013	Malibu	Body	Rear Seat Heating Control Module																																																											
1	2013	Malibu	Body	Keyless Entry Control Module																																																											
1	2013	Malibu	Body	Parking Assist Control Module																																																											
1	2013	Malibu	Body	Vehicle Direction Camera Control Module																																																											
1	2013	Malibu	Body	Steering Column Lock Control Module																																																											
1	2013	Malibu	Body	Battery Energy Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																											
1	2014	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																											
1	2014	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																											
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																											
1	2014	Impala	Chassis	Electronic Brake Control Module																																																											
1	2014	Impala	Chassis	Distance Sensing Cruise Control Module																																																											
1	2014	Impala	Chassis	Parking Brake Control Module																																																											
1	2014	Impala	Chassis	Power Steering Control Module																																																											
1	2014	Impala	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2014	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	Impala	Body	Passenger Presence Module																																																											
1	2014	Impala	Body	Instrument Cluster																																																											
1	2014	Impala	Body	Radio Control																																																											
1	2014	Impala	Body	HVAC Control																																																											
1	2014	Impala	Body	Radio																																																											
1	2014	Impala	Body	Amplifier																																																											
1	2014	Impala	Body	Human Machine Interface Control Module																																																											
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Impala	Body	HVAC Control Module																																																											
1	2014	Impala	Body	Keyless Entry Control Module																																																											
1	2014	Impala	Body	Right Side Object Detection Control Module																																																											
1	2014	Impala	Body	Left Side Object Detection Control Module																																																											
1	2014	Impala	Body	Parking Assist Control Module																																																											
1	2014	Impala	Body	Frontview Camera Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2014	Impala	Body	Steering Column Lock Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
1	2014	Malibu	Chassis	Electronic Brake Control Module																																																											
1	2014	Malibu	Chassis	Parking Brake Control Module																																																											
1	2014	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2014	Malibu	Chassis	Power Steering Control Module																																																											
1	2014	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Malibu	Chassis	Suspension Control Module																																																											
1	2014	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																				V																						
1	2014	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																				V																						
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																											
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																											
1	2014	Malibu	Body	Passenger Presence Module																																																											
1	2014	Malibu	Body	Instrument Cluster																																																											
1	2014	Malibu	Body	Headlamp Control Module																																																											
1	2014	Malibu	Body	Radio																																																										
1	2014	Malibu	Body	Digital Radio Receiver Control Module																																																											
1	2014	Malibu	Body	Multimedia Player Interface Module																																																											
1	2014	Malibu	Body	Mobile Telephone Control Module																																																											
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
1	2014	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2014	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2014	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
1	2014	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2014	Malibu	Body	Keyless Entry Control Module																																																										
1	2014	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2014	Malibu	Body	Parking Assist Control Module																																																										
1	2014	Malibu	Body	Frontview Camera Module																																																										
1	2014	Malibu	Body	Steering Column Lock Control Module																																																										
1	2015	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																										
1	2015	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																										
1	2015	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																										
1	2015	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																										
1	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																										
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																										
1	2015	Impala	Chassis	Electronic Brake Control Module																																																										
1	2015	Impala	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Impala	Chassis	Parking Brake Control Module																																																										
1	2015	Impala	Chassis	Power Steering Control Module																																																										
1	2015	Impala	Chassis	Power Steering Control Module																																																										
1	2015	Impala	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																				V																					
1	2015	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																				V																					
1	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Impala	Body	Passenger Presence Module																																																										
1	2015	Impala	Body	Instrument Cluster																																																										
1	2015	Impala	Body	Radio Control																																																										
1	2015	Impala	Body	HVAC Control																																																										
1	2015	Impala	Body	Radio																																																										
1	2015	Impala	Body	Amplifier																																																										
1	2015	Impala	Body	Human Machine Interface Control Module																																																										
1	2015	Impala	Body	Telematics Communication Interface Control Module																																																										
1	2015	Impala	Body	HVAC Control Module																																																										
1	2015	Impala	Body	Keyless Entry Control Module																																																										
1	2015	Impala	Body	Right Side Object Detection Control Module																																																										
1	2015	Impala	Body	Left Side Object Detection Control Module																																																										
1	2015	Impala	Body	Parking Assist Control Module																																																										
1	2015	Impala	Body	Frontview Camera Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Chassis Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBS Chassis Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2015	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																											
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
1	2015	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																											
1	2015	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
1	2015	Malibu	Powertrain	2.4L LE9 Chassis Control Module																																																											
1	2015	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																											
1	2015	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2015	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																											
1	2015	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																											
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																											
1	2015	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																											
1	2015	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Automatic Transmission																																																											
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Manual Transmission																																																											
1	2015	Malibu	Powertrain	3.0L LFW Chassis Control Module																																																											
1	2015	Malibu	Powertrain	3.0L LFW Transmission Control Module																																																											
1	2015	Malibu	Powertrain	Rear Differential Clutch Control Module																																																											
1	2015	Malibu	Chassis	Electronic Brake Control Module																																																											
1	2015	Malibu	Chassis	Parking Brake Control Module																																																											
1	2015	Malibu	Chassis	Power Steering Control Module																																																											
1	2015	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2015	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																				V																						
1	2015	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																				V																						
1	2015	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	Malibu	Body	Passenger Presence Module																																																											
1	2015	Malibu	Body	Instrument Cluster																																																											
1	2015	Malibu	Body	Headlamp Control Module																																																											
1	2015	Malibu	Body	Radio																																																										
1	2015	Malibu	Body	Digital Radio Receiver Control Module																																																										
1	2015	Malibu	Body	Multimedia Player Interface Module																																																										
1	2015	Malibu	Body	Mobile Telephone Control Module																																																										
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
1	2015	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
1	2015	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2015	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
1	2015	Malibu	Body	Front Seat Heating Control Module																																																										
1	2015	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2015	Malibu	Body	Keyless Entry Control Module																																																										
1	2015	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2015	Malibu	Body	Parking Assist Control Module																																																										
1	2015	Malibu	Body	Frontview Camera Module																																																										
1	2015	Malibu	Body	Steering Column Lock Control Module																																																										
1	2015	Malibu (LSG)	Powertrain	1.6L LLU Engine Control Module																																																										
1	2015	Malibu (LSG)	Powertrain	Transmission Control Module																																																										
1	2015	Malibu (LSG)	Powertrain	Rear Differential Clutch Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2015	Malibu (LSG)	Chassis	Electronic Brake Control Module																																																										
1	2015	Malibu (LSG)	Chassis	Parking Brake Control Module																																																										
1	2015	Malibu (LSG)	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Malibu (LSG)	Chassis	Suspension Control Module																																																										
1	2015	Malibu (LSG)	Body	Body Control Module																																																										
1	2015	Malibu (LSG)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Malibu (LSG)	Body	Instrument Cluster																																																										
1	2015	Malibu (LSG)	Body	Headlamp Control Module																																																										
1	2015	Malibu (LSG)	Body	Radio																																																										
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Malibu (LSG)	Body	HVAC Control Module																																																										
1	2015	Malibu (LSG)	Body	Front Seat Heating Control Module																																																										
1	2015	Malibu (LSG)	Body	Keyless Entry Control Module																																																										
1	2015	Malibu (LSG)	Body	Left Side Object Detection Control Module																																																										
1	2015	Malibu (LSG)	Body	Parking Assist Control Module																																																										
1	2015	Malibu (LSG)	Body	Frontview Camera Module																																																										
1	2015	Malibu (LSG)	Body	Steering Column Lock Control Module																																																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2016	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																										
1	2016	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																										
1	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2016	Impala	Powertrain	Chassis Control Module																																																										
1	2016	Impala	Chassis	Electronic Brake Control Module																																																										
1	2016	Impala	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Impala	Chassis	Parking Brake Control Module																																																										
1	2016	Impala	Chassis	Power Steering Control Module																																																										
1	2016	Impala	Chassis	Power Steering Control Module																																																										
1	2016	Impala	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2016	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Impala	Body	Passenger Presence Module																																																										
1	2016	Impala	Body	Instrument Cluster																																																										
1	2016	Impala	Body	Radio Control																																																										
1	2016	Impala	Body	HVAC Control																																																										
1	2016	Impala	Body	Radio																																																										
1	2016	Impala	Body	Amplifier																																																										
1	2016	Impala	Body	Human Machine Interface Control Module																																																										
1	2016	Impala	Body	Navigation Control Module																																																										
1	2016	Impala	Body	Telematics Communication Interface Control Module																																																										
1	2016	Impala	Body	HVAC Control Module																																																										
1	2016	Impala	Body	Seat Memory Control Module - Driver																																																										
1	2016	Impala	Body	Keyless Entry Control Module																																																										
1	2016	Impala	Body	Right Side Object Detection Control Module																																																										
1	2016	Impala	Body	Left Side Object Detection Control Module																																																										
1	2016	Impala	Body	Parking Assist Control Module																																																										
1	2016	Impala	Body	Frontview Camera Module																																																										
1	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2016	Malibu	Powertrain	Fuel Injector Control Module																																		V	V																							
1	2016	Malibu	Powertrain	Chassis Control Module																																																										
1	2016	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2016	Malibu	Chassis	Parking Brake Control Module																																																										
1	2016	Malibu	Chassis	Power Steering Control Module																																																										
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Malibu	Body	Passenger Presence Module																																																										
1	2016	Malibu	Body	Instrument Cluster																																																										
1	2016	Malibu	Body	Headlamp Control Module																																																										
1	2016	Malibu	Body	Radio																																																									
1	2016	Malibu	Body	Digital Radio Receiver Control Module																																																									
1	2016	Malibu	Body	Multimedia Player Interface Module																																																									
1	2016	Malibu	Body	Mobile Telephone Control Module																																																									
1	2016	Malibu	Body	Telematics Communication Interface Control Module																																																									
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																									
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																									
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																									
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																									
1	2016	Malibu	Body	Seat Memory Control Module																																																									
1	2016	Malibu	Body	Front Seat Heating Control Module																																																									
1	2016	Malibu	Body	Rear Seat Heating Control Module																																																									
1	2016	Malibu	Body	Keyless Entry Control Module																																																									
1	2016	Malibu	Body	Left Side Object Detection Control Module																																																									
1	2016	Malibu	Body	Parking Assist Control Module																																																									
1	2016	Malibu	Body	Frontview Camera Module																																																									

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2005	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																V	V																									
A	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																	V																									
A	2005	ALL	Powertrain	Transmission Control Module																																																										
A	2005	ALL	Chassis	Power Steering Control Module																																																										
A	2005	ALL	Chassis	Anti-lock Brake System																																																										
A	2005	ALL	Body	Body Control Module																																	V	V	V																								
A	2005	ALL	Body	Digital Radio Receiver																																																										
A	2005	ALL	Body	Instrument Panel																																																										
A	2005	ALL	Body	Radio																						V	V												V	V																							
A	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2006	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																V	V																									
A	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																	V																									
A	2006	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																						V	V																			
A	2006	ALL	Powertrain	Transmission Control Module																																																										
A	2006	ALL	Chassis	Power Steering Control Module																																																										
A	2006	ALL	Chassis	Anti-lock Brake System																																																										
A	2006	ALL	Body	Body Control Module																																	V		V					V																		
A	2006	ALL	Body	Digital Radio Receiver																																																										
A	2006	ALL	Body	Instrument Panel																																																										
A	2006	ALL	Body	Radio																						V	V												V	V																							
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2006	ALL	Body	Theft Deterrent Module																																																										
A	2007	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																V	V																									
A	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																									V																	
A	2007	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																						V	V																		
A	2007	ALL	Powertrain	Transmission Control Module																																																										
A	2007	ALL	Chassis	Power Steering Control Module																																																										
A	2007	ALL	Chassis	Electronic Brake Control Module																																																										
A	2007	ALL	Body	Body Control Module																																	V		V					V																		
A	2007	ALL	Body	Digital Radio Receiver																																																										
A	2007	ALL	Body	Instrument Panel Cluster																																																										
A	2007	ALL	Body	Passenger Presence System																																																										
A	2007	ALL	Body	Personal Audio Link Module																																																										
A	2007	ALL	Body	Radio																						V	V												V	V																							
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2007	ALL	Body	Theft Deterrent Module																																																										
A	2008	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																									V																	
A	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																									V																	
A	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																						V	V																		
A	2008	ALL	Powertrain	Transmission Control Module																																																										
A	2008	ALL	Chassis	Power Steering Control Module																																																										
A	2008	ALL	Chassis	Electronic Brake Control Module with VSES																																										V																
A	2008	ALL	Chassis	Electronic Brake Control Module without VSES																																																										
A	2008	ALL	Body	Body Control Module											V																						V		V									V												
A	2008	ALL	Body	Digital Radio Receiver																																																										
A	2008	ALL	Body	Instrument Panel Cluster																																																										
A	2008	ALL	Body	Passenger Presence System																																																										
A	2008	ALL	Body	Personal Audio Link Module																																																										
A	2008	ALL	Body	Radio																						V	V												V	V																							
A	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2008	ALL	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2009	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																								V																	
A	2009	ALL	Powertrain	(H)2.2L L4 LAP Engine Control Module																																																									
A	2009	ALL	Powertrain	Transmission Control Module																																																									
A	2009	ALL	Chassis	Power Steering Control Module																																																									
A	2009	ALL	Chassis	Electronic Brake Control Module with VSES																																									V																
A	2009	ALL	Chassis	Electronic Brake Control Module without VSES																																																									
A	2009	ALL	Body	Body Control Module											V																					V		V							V																
A	2009	ALL	Body	Digital Radio Receiver																																																									
A	2009	ALL	Body	Instrument Panel Cluster																																																									
A	2009	ALL	Body	Passenger Presence System																																																									
A	2009	ALL	Body	Personal Audio Link Module																																																									
A	2009	ALL	Body	Radio																						V	V												V	V																					
A	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2009	ALL	Body	Theft Deterrent Module																																																									
A	2010	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																									
A	2010	ALL	Powertrain	(5)2.2L L4 LAP Engine Control Module																																																									
A	2010	ALL	Powertrain	Transmission Control Module																																																									
A	2010	ALL	Chassis	Power Steering Control Module																																																									
A	2010	ALL	Chassis	Electronic Brake Control Module with VSES																																									V																
A	2010	ALL	Chassis	Electronic Brake Control Module without VSES																																																									
A	2010	ALL	Body	Body Control Module											V																					V		V							V																
A	2010	ALL	Body	Digital Radio Receiver																																																									
A	2010	ALL	Body	Driver Information Center																																																									
A	2010	ALL	Body	Instrument Panel Cluster																																																									
A	2010	ALL	Body	Passenger Presence System																																																									
A	2010	ALL	Body	Personal Audio Link Module																																																									
A	2010	ALL	Body	Radio																						V	V												V	V																					
A	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2010	ALL	Body	Theft Deterrent Module																																																									
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
A	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																									
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
A	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																									
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																											V															
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																											V															
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
A	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
A	2012	Cobalt	Chassis	Electronic Brake Control Module																																																									
A	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																									
A	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2012	Cobalt	Body	Body Control Module																																																									
A	2012	Cobalt	Body	Passenger Presence Module																																																									
A	2012	Cobalt	Body	Instrument Cluster																																																									
A	2012	Cobalt	Body	Radio																																																									
A	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																												V	V												
A	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																									
A	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
A	2012	Cobalt	Body	Front Seat Heating Control Module																																																											
A	2012	Cobalt	Body	Parking Assist Control Module																																																											
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																												V															
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																												V															
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
A	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
A	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																												V															
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																												V															
A	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
A	2013	Cobalt	Chassis	Electronic Brake Control Module																																																											
A	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2013	Cobalt	Body	Body Control Module																																																											
A	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2013	Cobalt	Body	Instrument Cluster																																																											
A	2013	Cobalt	Body	Radio																																																										
A	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																											
A	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											
A	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
A	2013	Cobalt	Body	Front Seat Heating Control Module																																																											
A	2013	Cobalt	Body	Parking Assist Control Module																																																											
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																												V															
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																												V															
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
A	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
A	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																												V															
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																												V															
A	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
A	2014	Cobalt	Chassis	Electronic Brake Control Module																																																											
A	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2014	Cobalt	Body	Body Control Module																																																											
A	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2014	Cobalt	Body	Instrument Cluster																																																											
A	2014	Cobalt	Body	Radio																																																										
A	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
A	2014	Cobalt	Body	Front Seat Heating Control Module																																																												
A	2014	Cobalt	Body	Parking Assist Control Module																																																												
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																												V																
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																												V																
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																												V																
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																												V																
A	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
A	2015	Cobalt	Chassis	Electronic Brake Control Module																																																												
A	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2015	Cobalt	Body	Body Control Module																																																												
A	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2015	Cobalt	Body	Instrument Cluster																																																												
A	2015	Cobalt	Body	Radio																																																												
A	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																												
A	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												
A	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
A	2015	Cobalt	Body	Front Seat Heating Control Module																																																												
A	2015	Cobalt	Body	Parking Assist Control Module																																																												
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																												V																
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																												V																
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																												V																
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																												V																
A	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
A	2016	Cobalt	Chassis	Electronic Brake Control Module																																																												
A	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2016	Cobalt	Body	Body Control Module																																																												
A	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2016	Cobalt	Body	Instrument Cluster																																																												
A	2016	Cobalt	Body	Radio Other																																																												
A	2016	Cobalt	Body	Radio (IOB)																																																												
A	2016	Cobalt	Body	Radio (UF7)																																																												
A	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
A	2016	Cobalt	Body	Front Seat Heating Control Module																																																												
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																													V	V	V	V	V	V	V	V	V	V
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																													V	V	V	V	V	V	V	V	V	V
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module																																																											
B	2010	Beat	Powertrain	Transmission Control Module																																																												
B	2010	Beat	Chassis	Electronic Brake Control Module																																																												
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												
B	2010	Beat	Chassis	Power Steering Control Module																																																												
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module																																																												
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
B	2010	Beat	Body	Instrument Cluster																																																												
B	2010	Beat	Body	Keyless Entry Control Module																																																												
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																													V	V	V	V	V	V	V	V	V	V
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																													V	V	V	V	V	V	V	V	V	V
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module																																																												
B	2011	Beat	Powertrain	Transmission Control Module																																																												
B	2011	Beat	Chassis	Electronic Brake Control Module																																																												
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												
B	2011	Beat	Chassis	Electric Power Steering Control Module																																																												
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module																																																												
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
B	2011	Beat	Body	Instrument Cluster																																																												
B	2011	Beat	Body	Keyless Entry Control Module																																																												
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module																																													V	V	V	V	V	V	V	V	V	V
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module																																																												
B	2012	Beat	Powertrain	Transmission Control Module																																																												
B	2012	Beat	Chassis	Electronic Brake Control Module																																																												
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												
B	2012	Beat	Chassis	Electric Power Steering Control Module																																																												
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module																																																												
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
B	2012	Beat	Body	Instrument Cluster																																																												
B	2012	Beat	Body	Keyless Entry Control Module																																																												
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module																																													V		V	V	V	V	V	V	V	V
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module																																																												
B	2013	Beat	Powertrain	Transmission Control Module																																																												
B	2013	Beat	Chassis	Electronic Brake Control Module																																																												
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												
B	2013	Beat	Chassis	Electric Power Steering Control Module																																																												
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module																																																												
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
B	2013	Beat	Body	Instrument Cluster																																																												
B	2013	Beat	Body	Keyless Entry Control Module																																																												
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module																																													V		V	V	V	V	V	V	V	V
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module																																																												
B	2014	Beat	Powertrain	Transmission Control Module																																																												
B	2014	Beat	Powertrain	Fuel Injector Control Module																																																												
B	2014	Beat	Chassis	Electronic Brake Control Module																																																												
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
B	2014	Beat	Chassis	Power Steering Control Module																																																														
B	2014	Beat	Chassis	Steering Wheel Angle Sensor Module																																																														
B	2014	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
B	2014	Beat	Body	Instrument Cluster																																																														
B	2014	Beat	Body	Telematics Communication Interface Control Module																																																														
B	2015	Beat	Powertrain	1.0L LEB Engine Control Module																																														V		V	V	V	V	V	V	V	V
B	2015	Beat	Powertrain	1.19L LC5 Engine Control Module																																																														
B	2015	Beat	Powertrain	Transmission Control Module																																																														
B	2015	Beat	Powertrain	Fuel Injector Control Module																																																														
B	2015	Beat	Chassis	Electronic Brake Control Module																																																														
B	2015	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																														
B	2015	Beat	Chassis	Power Steering Control Module																																																														
B	2015	Beat	Chassis	Steering Wheel Angle Sensor Module																																																														
B	2015	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
B	2015	Beat	Body	Instrument Cluster																																																														
B	2015	Beat	Body	Radio																																																														
B	2015	Beat	Body	Telematics Communication Interface Control Module																																																														
B	2015	Beat	Body	Keyless Entry Control Module																																																														
B	2016	Beat	Powertrain	1.0L LEB Engine Control Module																																																														
B	2016	Beat	Powertrain	1.19L LC5 Engine Control Module																																																														
B	2016	Beat	Powertrain	Transmission Control Module																																																														
B	2016	Beat	Chassis	Electronic Brake Control Module																																																														
B	2016	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																														
B	2016	Beat	Chassis	Power Steering Control Module																																																														
B	2016	Beat	Chassis	Steering Wheel Angle Sensor Module																																																														
B	2016	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
B	2016	Beat	Body	Instrument Cluster																																																														
B	2016	Beat	Body	Radio																																																														
B	2016	Beat	Body	Telematics Communication Interface Control Module																																																														
B	2016	Beat	Body	HVAC Control Module																																																														
B	2016	Beat	Body	Keyless Entry Control Module																																																														
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																														
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																														
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																														
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																														
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																														
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																														
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																														
B	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																														
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																														
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																														
B	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																														
B	2016	Cruze	Chassis	Electronic Brake Control Module																																																														
B	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																														
B	2016	Cruze	Chassis	Power Steering Control Module																																																														
B	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																														
B	2016	Cruze	Body	Body Control Module																																																														
B	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
B	2016	Cruze	Body	Passenger Presence Module																																																														
B	2016	Cruze	Body	Instrument Cluster																																																														
B	2016	Cruze	Body	Radio Controls																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
B	2016	Cruze	Body	HVAC Controls																																																													
B	2016	Cruze	Body	Trailer Interface Control Module																																																														
B	2016	Cruze	Body	Radio Base (IO3 IO7)																																																													
B	2016	Cruze	Body	Radio (IOA)																																																													
B	2016	Cruze	Body	Radio (IOB)																																																													
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																													
B	2016	Cruze	Body	Amplifier																																																													
B	2016	Cruze	Body	Multimedia Player Interface Module																																																													
B	2016	Cruze	Body	Human Machine Interface Control Module																																																													
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																													
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																													
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																													
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																													
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																													
B	2016	Cruze	Body	Keyless Entry Control Module																																																													
B	2016	Cruze	Body	Right Side Object Detection Control Module																																																													
B	2016	Cruze	Body	Left Side Object Detection Control Module																																																													
B	2016	Cruze	Body	Parking Assist Control Module																																																													
B	2016	Cruze	Body	Frontview Camera Module																																																													
B	2016	Cruze	Body	Steering Column Lock Control Module																																																													
B	2016	Cruze	Body	Long Range Radar Sensor Module																																																													
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																													
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																													
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																													
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																													
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																													
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																													
C	2010	Spark	Powertrain	Transmission Control Module																																																													
C	2010	Spark	Chassis	Electronic Brake Control Module																																																													
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																													
C	2010	Spark	Chassis	Electric Power Steering Control Module																																																													
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2010	Spark	Body	Passenger Presence Module																																																													
C	2010	Spark	Body	Instrument Cluster																																																													
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																													
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																													
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																													
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																													
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																													
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																													
C	2011	Spark	Powertrain	Transmission Control Module																																																													
C	2011	Spark	Chassis	Electronic Brake Control Module																																																													
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																													
C	2011	Spark	Chassis	Electric Power Steering Control Module																																																													
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2011	Spark	Body	Passenger Presence Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2011	Spark	Body	Instrument Cluster																																																											
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																												
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																												
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																												
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																												
C	2012	Spark	Powertrain	Transmission Control Module																																																												
C	2012	Spark	Chassis	Electronic Brake Control Module																																																												
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2012	Spark	Chassis	Electric Power Steering Control Module																																																												
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2012	Spark	Body	Passenger Presence Module																																																												
C	2012	Spark	Body	Instrument Cluster																																																												
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																												
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																												
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																														V													
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																														V													
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																												
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																												
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
C	2013	Spark	Powertrain	Fuel Injector Control Module																																																												
C	2013	Spark	Chassis	Electronic Brake Control Module																																																												
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2013	Spark	Chassis	Power Steering Control Module																																																												
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2013	Spark	Body	Body Control Module																																																												
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2013	Spark	Body	Passenger Presence Module																																																												
C	2013	Spark	Body	Instrument Cluster																																																												
C	2013	Spark	Body	Radio																																																												
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																												
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																												
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																										V														
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																										V														
C	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																								
C	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
C	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																								
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																										V														
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																										V														
C	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																								
C	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																								
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
C	2014	Spark	Powertrain	Fuel Injector Control Module																																																								
C	2014	Spark	Chassis	Electronic Brake Control Module																																																								
C	2014	Spark	Chassis	Electronic Brake Control Module																																																								
C	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
C	2014	Spark	Chassis	Power Steering Control Module																																																								
C	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2014	Spark	Body	Body Control Module																																																								
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Spark	Body	Passenger Presence Module																																																								
C	2014	Spark	Body	Instrument Cluster																																																								
C	2014	Spark	Body	Radio																																																								
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																								
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2014	Spark	Body	Keyless Entry Control Module																																																								
C	2014	Spark EV	Powertrain	Engine Control Module																																																								
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																								
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V																																																							
C	2014	Spark EV	Powertrain	Drive Motor Control Module																																																								
C	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								
C	2014	Spark EV	Chassis	Electronic Brake Control Module		V	V																																																					
C	2014	Spark EV	Chassis	Parking Brake Control Module																																																								
C	2014	Spark EV	Chassis	Power Steering Control Module																																																								
C	2014	Spark EV	Body	Body Control Module																																																								
C	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
C	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Spark EV	Body	Passenger Presence Module																																																								
C	2014	Spark EV	Body	Instrument Cluster																																																								
C	2014	Spark EV	Body	Radio																																																								
C	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2014	Spark EV	Body	HVAC Control Module																																																								
C	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																								
C	2014	Spark EV	Body	Coolant Heater Control Module																																																								
C	2014	Spark EV	Body	Keyless Entry Control Module																																																								
C	2014	Spark EV	Body	Battery Charger Control Module																																																								
C	2014	Spark EV	Body	DC Charging Control Module																																																								
C	2014	Spark EV	Body	Battery Energy Control Module				V	V	V	V																																																	

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																												
C	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																												
C	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																												
C	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
C	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																												V															
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																												V															
C	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																												
C	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
C	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																												V															
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																												V															
C	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																												
C	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																												
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
C	2015	Spark	Powertrain	Fuel Injector Control Module																																																												
C	2015	Spark	Chassis	Electronic Brake Control Module																																																												
C	2015	Spark	Chassis	Electronic Brake Control Module																																																												
C	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2015	Spark	Chassis	Power Steering Control Module																																																												
C	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2015	Spark	Body	Body Control Module																																																												
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Spark	Body	Passenger Presence Module																																																												
C	2015	Spark	Body	Instrument Cluster																																																												
C	2015	Spark	Body	Instrument Cluster																																																												
C	2015	Spark	Body	Tire Pressure Indicator Module																																																												
C	2015	Spark	Body	Radio																																																												
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2015	Spark	Body	Keyless Entry Control Module																																																												
C	2015	Spark EV	Powertrain	Engine Control Module																																																												
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																												
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V																																																											
C	2015	Spark EV	Powertrain	Drive Motor Control Module																																																												
C	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																												
C	2015	Spark EV	Chassis	Electronic Brake Control Module		V	V																																																									
C	2015	Spark EV	Chassis	Parking Brake Control Module																																																												
C	2015	Spark EV	Chassis	Power Steering Control Module																																																												
C	2015	Spark EV	Body	Body Control Module																																																												
C	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																												
C	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Spark EV	Body	Passenger Presence Module																																																												
C	2015	Spark EV	Body	Instrument Cluster																																																												
C	2015	Spark EV	Body	Radio																																																											
C	2015	Spark EV	Body	HVAC Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																												
C	2015	Spark EV	Body	Coolant Heater Control Module																																																													
C	2015	Spark EV	Body	Keyless Entry Control Module																																																													
C	2015	Spark EV	Body	Battery Charger Control Module																																																													
C	2015	Spark EV	Body	DC Charging Control Module																																																													
C	2015	Spark EV	Body	Battery Energy Control Module				V	V	V	V																																																					
C	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																													
C	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																													
C	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																													
C	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																													
C	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																													
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																													
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																													
C	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																													
C	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																													
C	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																													
C	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																													
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																													
C	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																													
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																													
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																													V															
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																													V															
C	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																													
C	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																													
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																													
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																													
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																													
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																													
C	2016	Spark	Powertrain	Fuel Injector Control Module																																																													
C	2016	Spark	Chassis	Electronic Brake Control Module																																																													
C	2016	Spark	Chassis	Electronic Brake Control Module																																																													
C	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																													
C	2016	Spark	Chassis	Power Steering Control Module																																																													
C	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2016	Spark	Body	Body Control Module																																																													
C	2016	Spark	Body	Body Control Module																																																													
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	Spark	Body	Instrument Cluster																																																													
C	2016	Spark	Body	Instrument Cluster																																																													
C	2016	Spark	Body	Radio																																																												
C	2016	Spark	Body	Telematics Communication Interface Control Module																																																													
C	2016	Spark	Body	Keyless Entry Control Module																																																													
C	2016	Spark EV	Powertrain	Engine Control Module																																																													
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																													
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V							V																																																				
C	2016	Spark EV	Powertrain	Drive Motor Control Module																																																													
C	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																													
C	2016	Spark EV	Chassis	Electronic Brake Control Module		V	V																																																										
C	2016	Spark EV	Chassis	Parking Brake Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2016	Spark EV	Chassis	Power Steering Control Module																																																												
C	2016	Spark EV	Body	Body Control Module																																																												
C	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																												
C	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Spark EV	Body	Passenger Presence Module																																																												
C	2016	Spark EV	Body	Instrument Cluster																																																												
C	2016	Spark EV	Body	Radio																																																												
C	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																												
C	2016	Spark EV	Body	HVAC Control Module																																																												
C	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																												
C	2016	Spark EV	Body	Coolant Heater Control Module																																																												
C	2016	Spark EV	Body	Keyless Entry Control Module																																																												
C	2016	Spark EV	Body	Frontview Camera Module																																																												
C	2016	Spark EV	Body	Battery Charger Control Module																																																												
C	2016	Spark EV	Body	DC Charging Control Module																																																												
C	2016	Spark EV	Body	Battery Energy Control Module				V	V	V	V																																																					
D	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
D	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
D	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
D	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
D	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
D	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
D	2010	Spark	Powertrain	Transmission Control Module																																																												
D	2010	Spark	Chassis	Electronic Brake Control Module																																																												
D	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
D	2010	Spark	Chassis	Electric Power Steering Control Module																																																												
D	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2010	Spark	Body	Passenger Presence Module																																																												
D	2010	Spark	Body	Instrument Cluster																																																												
D	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
D	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
D	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
D	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
D	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																												
D	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																												
D	2011	Spark	Powertrain	Transmission Control Module																																																												
D	2011	Spark	Chassis	Electronic Brake Control Module																																																												
D	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
D	2011	Spark	Chassis	Electric Power Steering Control Module																																																												
D	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2011	Spark	Body	Passenger Presence Module																																																												
D	2011	Spark	Body	Instrument Cluster																																																												
D	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
D	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
D	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
D	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
D	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																														
D	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																														
D	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																														
D	2012	Spark	Powertrain	Transmission Control Module																																																														
D	2012	Spark	Chassis	Electronic Brake Control Module																																																														
D	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																														
D	2012	Spark	Chassis	Electric Power Steering Control Module																																																														
D	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																														
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
D	2012	Spark	Body	Passenger Presence Module																																																														
D	2012	Spark	Body	Instrument Cluster																																																														
D	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																														
D	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																														
D	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																														
D	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																														
D	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																														
D	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																														
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																												V																
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																												V																
D	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																														
D	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																														
D	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																														
D	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																														
D	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																														
D	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																														
D	2013	Spark	Powertrain	Fuel Injector Control Module																																																														
D	2013	Spark	Chassis	Electronic Brake Control Module																																																														
D	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																														
D	2013	Spark	Chassis	Power Steering Control Module																																																														
D	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																														
D	2013	Spark	Body	Body Control Module																																																														
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
D	2013	Spark	Body	Passenger Presence Module																																																														
D	2013	Spark	Body	Instrument Cluster																																																														
D	2013	Spark	Body	Radio																																																														
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																														
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																														
D	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																														
D	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																														
D	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																														
D	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																														
D	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																														
D	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																														
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																												V																
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																												V																
D	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																														
D	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																														
D	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																														
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																											V															
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																											V															
D	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2014	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2014	Spark	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2014	Spark	Chassis	Power Steering Control Module																																																											
D	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2014	Spark	Body	Body Control Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Passenger Presence Module																																																											
D	2014	Spark	Body	Instrument Cluster																																																											
D	2014	Spark	Body	Radio																																																											
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark	Body	Keyless Entry Control Module																																																											
D	2014	Spark EV	Powertrain	Engine Control Module																																																											
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V																																																										
D	2014	Spark EV	Powertrain	Drive Motor Control Module																																																											
D	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
D	2014	Spark EV	Chassis	Electronic Brake Control Module		V	V																																																								
D	2014	Spark EV	Chassis	Parking Brake Control Module																																																											
D	2014	Spark EV	Chassis	Power Steering Control Module																																																											
D	2014	Spark EV	Body	Body Control Module																																																											
D	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
D	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark EV	Body	Passenger Presence Module																																																											
D	2014	Spark EV	Body	Instrument Cluster																																																											
D	2014	Spark EV	Body	Radio																																																										
D	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark EV	Body	HVAC Control Module																																																											
D	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																											
D	2014	Spark EV	Body	Coolant Heater Control Module																																																											
D	2014	Spark EV	Body	Keyless Entry Control Module																																																											
D	2014	Spark EV	Body	Battery Charger Control Module																																																											
D	2014	Spark EV	Body	DC Charging Control Module																																																											
D	2014	Spark EV	Body	Battery Energy Control Module				V	V	V	V																																																				
D	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
D	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
D	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																											V															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																											V														
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																									
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																									
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																									
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																									
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																											V														
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																											V														
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																									
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																									
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																									
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
D	2015	Spark	Powertrain	Fuel Injector Control Module																																																									
D	2015	Spark	Chassis	Electronic Brake Control Module																																																									
D	2015	Spark	Chassis	Electronic Brake Control Module																																																									
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
D	2015	Spark	Chassis	Power Steering Control Module																																																									
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
D	2015	Spark	Body	Body Control Module																																																									
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2015	Spark	Body	Passenger Presence Module																																																									
D	2015	Spark	Body	Instrument Cluster																																																									
D	2015	Spark	Body	Instrument Cluster																																																									
D	2015	Spark	Body	Tire Pressure Indicator Module																																																									
D	2015	Spark	Body	Radio																																																									
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																									
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																									
D	2015	Spark	Body	Keyless Entry Control Module																																																									
D	2015	Spark EV	Powertrain	Engine Control Module																																																									
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																									
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V																																																								
D	2015	Spark EV	Powertrain	Drive Motor Control Module																																																									
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																									
D	2015	Spark EV	Chassis	Electronic Brake Control Module		V	V																																																							
D	2015	Spark EV	Chassis	Parking Brake Control Module																																																									
D	2015	Spark EV	Chassis	Power Steering Control Module																																																									
D	2015	Spark EV	Body	Body Control Module																																																									
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																									
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2015	Spark EV	Body	Passenger Presence Module																																																									
D	2015	Spark EV	Body	Instrument Cluster																																																									
D	2015	Spark EV	Body	Radio																																																									
D	2015	Spark EV	Body	HVAC Control Module																																																									
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																									
D	2015	Spark EV	Body	Coolant Heater Control Module																																																									
D	2015	Spark EV	Body	Keyless Entry Control Module																																																									
D	2015	Spark EV	Body	Battery Charger Control Module																																																									
D	2015	Spark EV	Body	DC Charging Control Module																																																									
D	2015	Spark EV	Body	Battery Energy Control Module				V	V	V	V																																																		

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																														
D	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																														
D	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																														
D	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																														
D	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																														
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																														
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																														
D	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																														
D	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																														
D	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																														
D	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																														
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																														
D	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																														
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																														
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																												V																	
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																												V																	
D	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																														
D	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																														
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																														
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																														
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																														
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																														
D	2016	Spark	Powertrain	Fuel Injector Control Module																																																														
D	2016	Spark	Chassis	Electronic Brake Control Module																																																														
D	2016	Spark	Chassis	Electronic Brake Control Module																																																														
D	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																														
D	2016	Spark	Chassis	Power Steering Control Module																																																														
D	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																														
D	2016	Spark	Body	Body Control Module																																																														
D	2016	Spark	Body	Body Control Module																																																														
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
D	2016	Spark	Body	Instrument Cluster																																																														
D	2016	Spark	Body	Instrument Cluster																																																														
D	2016	Spark	Body	Radio																																																														
D	2016	Spark	Body	Telematics Communication Interface Control Module																																																														
D	2016	Spark	Body	Keyless Entry Control Module																																																														
D	2016	Spark EV	Powertrain	Engine Control Module																																																															
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																														
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V							V																																																					
D	2016	Spark EV	Powertrain	Drive Motor Control Module																																																														
D	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																														
D	2016	Spark EV	Chassis	Electronic Brake Control Module		V	V																																																										
D	2016	Spark EV	Chassis	Parking Brake Control Module																																																														
D	2016	Spark EV	Chassis	Power Steering Control Module																																																														
D	2016	Spark EV	Body	Body Control Module																																																														
D	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																														
D	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
D	2016	Spark EV	Body	Passenger Presence Module																																																														
D	2016	Spark EV	Body	Instrument Cluster																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2016	Spark EV	Body	Radio																																																											
D	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																											
D	2016	Spark EV	Body	HVAC Control Module																																																											
D	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																											
D	2016	Spark EV	Body	Coolant Heater Control Module																																																											
D	2016	Spark EV	Body	Keyless Entry Control Module																																																											
D	2016	Spark EV	Body	Frontview Camera Module																																																											
D	2016	Spark EV	Body	Battery Charger Control Module																																																											
D	2016	Spark EV	Body	DC Charging Control Module																																																											
D	2016	Spark EV	Body	Battery Energy Control Module				V	V	V	V																																																				
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Automatic Transmission																																																											
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Manual Transmission																																																											
F	2010	Camaro	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																											
F	2010	Camaro	Powertrain	(V) 3.6L LLT Transmission Control Module																																																											
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2010	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																											
F	2010	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																											
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																											
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2010	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2010	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2010	Camaro	Chassis	Power Steering Control Module																																																											
F	2010	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2010	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2010	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2010	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2010	Camaro	Body	Passenger Presence Module																																																											
F	2010	Camaro	Body	Instrument Cluster																																																											
F	2010	Camaro	Body	Auxiliary Gage Module																																																											
F	2010	Camaro	Body	Radio																																																											
F	2010	Camaro	Body	Multimedia Player Interface Module																																																											
F	2010	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																											
F	2010	Camaro	Body	Mobile Telephone Control Module																																																											
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2010	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																											
F	2010	Camaro	Body	Front Seat Heating Control Module																																																											
F	2010	Camaro	Body	Folding Top Control Module																																																											
F	2010	Camaro	Body	Parking Assist Control Module																																																											
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Automatic Transmission																																																											
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Manual Transmission																																																											
F	2011	Camaro	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																											
F	2011	Camaro	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2011	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																											
F	2011	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																											
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																												
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2011	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2011	Camaro	Chassis	Power Steering Control Module																																																												
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2011	Camaro	Body	Passenger Presence Module																																																												
F	2011	Camaro	Body	Instrument Cluster																																																												
F	2011	Camaro	Body	Head-Up Display Module																																																												
F	2011	Camaro	Body	Auxiliary Gage Module																																																												
F	2011	Camaro	Body	Headlamp Control Module																																																												
F	2011	Camaro	Body	Radio																																																											
F	2011	Camaro	Body	Multimedia Player Interface Module																																																												
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																												
F	2011	Camaro	Body	Mobile Telephone Control Module																																																												
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																												
F	2011	Camaro	Body	Front Seat Heating Control Module																																																												
F	2011	Camaro	Body	Folding Top Control Module																																																												
F	2011	Camaro	Body	Parking Assist Control Module																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																												
F	2012	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2012	Camaro	Chassis	Power Steering Control Module																																																												
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2012	Camaro	Chassis	Suspension Control Module																																																												
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2012	Camaro	Body	Passenger Presence Module																																																												
F	2012	Camaro	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
F	2012	Camaro	Body	Head-Up Display Module																																																												
F	2012	Camaro	Body	Auxiliary Gage Module																																																												
F	2012	Camaro	Body	Headlamp Control Module																																																												
F	2012	Camaro	Body	Radio																																																												
F	2012	Camaro	Body	Multimedia Player Interface Module																																																												
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																												
F	2012	Camaro	Body	Mobile Telephone Control Module																																																												
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																												
F	2012	Camaro	Body	Front Seat Heating Control Module																																																												
F	2012	Camaro	Body	Folding Top Control Module																																																												
F	2012	Camaro	Body	Parking Assist Control Module																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																												
F	2013	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2013	Camaro	Chassis	Power Steering Control Module																																																												
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2013	Camaro	Chassis	Suspension Control Module																																																												
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2013	Camaro	Body	Passenger Presence Module																																																												
F	2013	Camaro	Body	Instrument Cluster																																																												
F	2013	Camaro	Body	Head-Up Display Module																																																												
F	2013	Camaro	Body	Auxiliary Gage Module																																																												
F	2013	Camaro	Body	Headlamp Control Module																																																												
F	2013	Camaro	Body	Radio																																																											
F	2013	Camaro	Body	Multimedia Player Interface Module																																																												
F	2013	Camaro	Body	Mobile Telephone Control Module																																																												
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
F	2013	Camaro	Body	HVAC Control Module																																																											
F	2013	Camaro	Body	Front Seat Heating Control Module																																																												
F	2013	Camaro	Body	Folding Top Control Module																																																												
F	2013	Camaro	Body	Parking Assist Control Module																																																												
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																												
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																												
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																												
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																												
F	2014	Camaro	Powertrain	Transmission Control Module																																																												
F	2014	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2014	Camaro	Chassis	Parking Brake Control Module																																																												
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2014	Camaro	Chassis	Power Steering Control Module																																																												
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2014	Camaro	Chassis	Suspension Control Module																																																												
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2014	Camaro	Body	Passenger Presence Module																																																												
F	2014	Camaro	Body	Instrument Cluster																																																												
F	2014	Camaro	Body	Head-Up Display Module																																																												
F	2014	Camaro	Body	Auxiliary Gage Module																																																												
F	2014	Camaro	Body	Headlamp Control Module																																																												
F	2014	Camaro	Body	Radio																																																											
F	2014	Camaro	Body	Mobile Telephone Control Module																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2014	Camaro	Body	HVAC Control Module																																																											
F	2014	Camaro	Body	Front Seat Heating Control Module																																																											
F	2014	Camaro	Body	Folding Top Control Module																																																											
F	2014	Camaro	Body	Parking Assist Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2014	SS	Powertrain	Chassis Control Module																																																											
F	2014	SS	Chassis	Electronic Brake Control Module																																																											
F	2014	SS	Chassis	Parking Brake Control Module																																																											
F	2014	SS	Chassis	Power Steering Control Module																																																											
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2014	SS	Body	Body Control Module																																																											
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2014	SS	Body	Passenger Presence Module																																																											
F	2014	SS	Body	Instrument Cluster																																																											
F	2014	SS	Body	Head-Up Display Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
F	2014	SS	Body	Radio Control																																																												
F	2014	SS	Body	HVAC Control																																																												
F	2014	SS	Body	Headlamp Control Module																																																												
F	2014	SS	Body	Trailer Interface Control Module																																																												
F	2014	SS	Body	Radio																																																												
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2014	SS	Body	HVAC Control Module																																																												
F	2014	SS	Body	Seat Memory Control Module - Driver																																																												
F	2014	SS	Body	Keyless Entry Control Module																																																												
F	2014	SS	Body	Right Side Object Detection Control Module																																																												
F	2014	SS	Body	Left Side Object Detection Control Module																																																												
F	2014	SS	Body	Parking Assist Control Module																																																												
F	2014	SS	Body	Frontview Camera Module																																																												
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																												
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																												
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																												
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																												
F	2015	Camaro	Powertrain	Transmission Control Module																																																												
F	2015	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2015	Camaro	Chassis	Power Steering Control Module																																																												
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2015	Camaro	Chassis	Suspension Control Module																																																												
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2015	Camaro	Body	Passenger Presence Module																																																												
F	2015	Camaro	Body	Instrument Cluster																																																												
F	2015	Camaro	Body	Head-Up Display Module																																																												
F	2015	Camaro	Body	Auxiliary Gage Module																																																												
F	2015	Camaro	Body	Headlamp Control Module																																																												
F	2015	Camaro	Body	Radio																																																												
F	2015	Camaro	Body	Mobile Telephone Control Module																																																												
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6																																																												
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																												
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2015	Camaro	Body	HVAC Control Module																																																												
F	2015	Camaro	Body	Front Seat Heating Control Module																																																												
F	2015	Camaro	Body	Folding Top Control Module																																																												
F	2015	Camaro	Body	Parking Assist Control Module																																																												
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																														
F	2015	SS	Powertrain	Fuel Injector Control Module																																																															
F	2015	SS	Powertrain	Chassis Control Module																																																															
F	2015	SS	Chassis	Electronic Brake Control Module																																																															
F	2015	SS	Chassis	Parking Brake Control Module																																																															
F	2015	SS	Chassis	Power Steering Control Module																																																															
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module																																																															
F	2015	SS	Chassis	Suspension Control Module																																																															
F	2015	SS	Body	Body Control Module																																																															
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
F	2015	SS	Body	Passenger Presence Module																																																															
F	2015	SS	Body	Instrument Cluster																																																															
F	2015	SS	Body	Head-Up Display Module																																																															
F	2015	SS	Body	Radio Control																																																															
F	2015	SS	Body	HVAC Control																																																															
F	2015	SS	Body	Headlamp Control Module																																																															
F	2015	SS	Body	Trailer Interface Control Module																																																															
F	2015	SS	Body	Radio																																																															
F	2015	SS	Body	Telematics Communication Interface Control Module																																																															
F	2015	SS	Body	HVAC Control Module																																																															
F	2015	SS	Body	Seat Memory Control Module - Driver																																																															
F	2015	SS	Body	Keyless Entry Control Module																																																															
F	2015	SS	Body	Right Side Object Detection Control Module																																																															
F	2015	SS	Body	Left Side Object Detection Control Module																																																															
F	2015	SS	Body	Parking Assist Control Module																																																															
F	2015	SS	Body	Frontview Camera Module																																																															
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																															
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																															
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																															
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																															
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																															
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																															
F	2016	Camaro	Powertrain	Transmission Control Module																																																															
F	2016	Camaro	Chassis	Electronic Brake Control Module																																																															
F	2016	Camaro	Chassis	Parking Brake Control Module																																																															
F	2016	Camaro	Chassis	Power Steering Control Module																																																															
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																															
F	2016	Camaro	Chassis	Suspension Control Module																																																															
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																															
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																															
F	2016	Camaro	Body	Serial Data Gateway Module																																																															
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
F	2016	Camaro	Body	Passenger Presence Module																																																															
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																															
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																															
F	2016	Camaro	Body	Head-Up Display Module																																																															
F	2016	Camaro	Body	Auxiliary Gage Module																																																															
F	2016	Camaro	Body	Radio Controls																																																															
F	2016	Camaro	Body	HVAC Controls																																																															
F	2016	Camaro	Body	Vehicle Performance Data Recorder																																																															
F	2016	Camaro	Body	Radio																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
F	2016	Camaro	Body	Amplifier																																																											
F	2016	Camaro	Body	Media Disc Player																																																											
F	2016	Camaro	Body	Human Machine Interface Control Module																																																											
F	2016	Camaro	Body	Navigation Control Module																																																											
F	2016	Camaro	Body	Mobile Telephone Control Module																																																											
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																											
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)																																																											
F	2016	Camaro	Body	Seat Memory Control Module - Driver																																																											
F	2016	Camaro	Body	Folding Top Control Module																																																											
F	2016	Camaro	Body	Keyless Entry Control Module																																																											
F	2016	Camaro	Body	Right Side Object Detection Control Module																																																											
F	2016	Camaro	Body	Left Side Object Detection Control Module																																																											
F	2016	Camaro	Body	Parking Assist Control Module																																																											
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2016	SS	Powertrain	Fuel Injector Control Module																																																											
F	2016	SS	Chassis	Electronic Brake Control Module																																																											
F	2016	SS	Chassis	Parking Brake Control Module																																																											
F	2016	SS	Chassis	Power Steering Control Module																																																											
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2016	SS	Chassis	Suspension Control Module																																																											
F	2016	SS	Body	Body Control Module																																																											
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2016	SS	Body	Passenger Presence Module																																																											
F	2016	SS	Body	Instrument Cluster																																																											
F	2016	SS	Body	Head-Up Display Module																																																											
F	2016	SS	Body	Radio Control																																																											
F	2016	SS	Body	HVAC Control																																																											
F	2016	SS	Body	Trailer Interface Control Module																																																											
F	2016	SS	Body	Radio																																																											
F	2016	SS	Body	Telematics Communication Interface Control Module																																																											
F	2016	SS	Body	HVAC Control Module																																																											
F	2016	SS	Body	Seat Memory Control Module - Driver																																																											
F	2016	SS	Body	Keyless Entry Control Module																																																											
F	2016	SS	Body	Right Side Object Detection Control Module																																																											
F	2016	SS	Body	Left Side Object Detection Control Module																																																											
F	2016	SS	Body	Parking Assist Control Module																																																											
F	2016	SS	Body	Frontview Camera Module																																																											
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																											
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																											
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
G	2016	Malibu	Powertrain	Fuel Injector Control Module																																																											
G	2016	Malibu	Powertrain	Chassis Control Module																																																											
G	2016	Malibu	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2016	Malibu	Chassis	Parking Brake Control Module																																																												
G	2016	Malibu	Chassis	Power Steering Control Module																																																												
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																												
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2016	Malibu	Body	Passenger Presence Module																																																												
G	2016	Malibu	Body	Instrument Cluster																																																												
G	2016	Malibu	Body	Headlamp Control Module																																																												
G	2016	Malibu	Body	Radio																																																											
G	2016	Malibu	Body	Digital Radio Receiver Control Module																																																												
G	2016	Malibu	Body	Multimedia Player Interface Module																																																												
G	2016	Malibu	Body	Mobile Telephone Control Module																																																												
G	2016	Malibu	Body	Telematics Communication Interface Control Module																																																												
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																												
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																												
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																												
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																												
G	2016	Malibu	Body	Seat Memory Control Module																																																												
G	2016	Malibu	Body	Front Seat Heating Control Module																																																												
G	2016	Malibu	Body	Rear Seat Heating Control Module																																																												
G	2016	Malibu	Body	Keyless Entry Control Module																																																												
G	2016	Malibu	Body	Left Side Object Detection Control Module																																																												
G	2016	Malibu	Body	Parking Assist Control Module																																																												
G	2016	Malibu	Body	Frontview Camera Module																																																												
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																												
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																												
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																												
H	2010	Sail	Powertrain	Transmission Control Module																																																												
H	2010	Sail	Chassis	Electronic Brake Control Module																																																												
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																												
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																												
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																												
H	2011	Sail	Powertrain	Transmission Control Module																																																												
H	2011	Sail	Chassis	Electronic Brake Control Module																																																												
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																												
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																												
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																												
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																												
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																												
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																												
H	2012	Sail	Powertrain	Transmission Control Module																																																												
H	2012	Sail	Chassis	Electronic Brake Control Module																																																												
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																												
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																												
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																													
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																													
H	2013	Sail	Powertrain	Transmission Control Module																																																													
H	2013	Sail	Chassis	Electronic Brake Control Module																																																													
H	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																													
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																													
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																													
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																													
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																													
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																													
H	2014	Sail	Powertrain	Transmission Control Module																																																													
H	2014	Sail	Chassis	Electronic Brake Control Module																																																													
H	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
H	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																													
H	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																													
H	2015	Sail	Chassis	Electronic Brake Control Module																																																													
H	2015	Sail	Chassis	Power Steering Control Module																																																													
H	2015	Sail	Body	Body Control Module																																																												
H	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2015	Sail	Body	Radio/HVAC Control																																																												
H	2015	Sail	Body	HVAC Control Module																																																												
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																												
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																												
H	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																												
H	2016	Sail	Chassis	Electronic Brake Control Module																																																												
H	2016	Sail	Chassis	Power Steering Control Module																																																												
H	2016	Sail	Body	Body Control Module																																																											
H	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2016	Sail	Body	Radio/HVAC Control																																																												
H	2016	Sail	Body	Radio																																																											
H	2016	Sail	Body	HVAC Control Module																																																											
J	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
J	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
J	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																												
J	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
J	2004	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																												
J	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																												
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																												
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																												
J	2004	Optra	Body	Remote Function Actuation																																																												
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel																																																												
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel Transmission Control Module																																																												
J	2004	Cavalier	Chassis	Anti-lock Brake System																																																												
J	2004	Cavalier	Body	Body Control Module										V																																																	
J	2004	Cavalier	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2004	Cavalier	Body	Instrument Panel Cluster																																																												
J	2004	Cavalier	Body	Radio																																																												
J	2004	Cavalier	Body	Supplemental Inflatable Restraint																																																												
J	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
J	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
J	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																												
J	2005	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																												
J	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																												
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																												
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																												
J	2005	Optra	Body	Remote Function Actuation																																																												
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
J	2005	Cavalier	Chassis	Anti-lock Brake System																																																												
J	2005	Cavalier	Body	Body Control Module										V																																																	
J	2005	Cavalier	Body	Digital Radio Receiver																																																												
J	2005	Cavalier	Body	Instrument Panel Cluster																																																												
J	2005	Cavalier	Body	Radio																																																											
J	2005	Cavalier	Body	Supplemental Inflatable Restraint																																																											
J	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
J	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
J	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																												
J	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
J	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
J	2006	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																												
J	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																												
J	2006	ALL	Body	Remote Function Actuation																																																												
J	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
J	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
J	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
J	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
J	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
J	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																												
J	2007	ALL	Powertrain	4 Speed Automatic																																																												
J	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
J	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																												
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																												
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																												
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																												
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																												
J	2007	ALL	Chassis	Tire Pressure Monitor																																																												
J	2007	ALL	Body	Remote Function Actuation																																																												
J	2007	ALL	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																														
J	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																															
J	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																															
J	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																															
J	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																															
J	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																															
J	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																															
J	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																																																															
J	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																															
J	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
J	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																															
J	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																															
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																															
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																															
J	2008	ALL	Chassis	Tire Pressure Monitor																																																															
J	2008	ALL	Body	Remote Function Actuation																																																															
J	2008	ALL	Body	Supplemental Inflatable Restraint																																																															
J	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
J	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																															
J	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																															
J	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																															
J	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																															
J	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																															
J	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																															
J	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																															
J	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
J	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																															
J	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																															
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																															
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																															
J	2009	ALL	Chassis	Tire Pressure Monitor																																																															
J	2009	ALL	Body	Remote Function Actuation																																																															
J	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																															
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																															
J	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																															
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																															
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																															
J	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																															
J	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																															
J	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																															
J	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																															
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																															
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																															
J	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																															
J	2010	Cruze	Chassis	Electronic Brake Control Module																																																															
J	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																															
J	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																															
J	2010	Cruze	Body	Body Control Module																																																															
J	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
J	2010	Cruze	Body	Passenger Presence Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2010	Cruze	Body	Instrument Cluster																																																														
J	2010	Cruze	Body	Trailer Interface Control Module																																																														
J	2010	Cruze	Body	Radio																																																													
J	2010	Cruze	Body	Multimedia Player Interface Module																																																													
J	2010	Cruze	Body	Mobile Telephone Control Module																																																													
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																													
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																													
J	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																													
J	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																													
J	2010	Cruze	Body	Keyless Entry Control Module																																																													
J	2010	Cruze	Body	Parking Assist Control Module																																																													
J	2010	Cruze	Body	Steering Column Lock Control Module																																																													
J	2010	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
J	2010	Other	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																													
J	2010	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																													
J	2010	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																													
J	2010	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																													
J	2010	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																													
J	2010	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																													
J	2010	Other	Powertrain	Transmission Control Module 5 Speed																																																													
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																													
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control No																																																													
J	2010	Other	Chassis	Tire Pressure Monitor																																																													
J	2010	Other	Body	Remote Function Actuation																																																													
J	2010	Other	Body	Supplemental Inflatable Restraint																																																													
J	2010	Other	Body	Supplemental Inflatable Restraint																																																													
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																													
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																													
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																													
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																													
J	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																													
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																													
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																													
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																													
J	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																													
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																													
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																													
J	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																													
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																													
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																													
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																													
J	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																													
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																													
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																													
J	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																													
J	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																													
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																											
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																												
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
J	2011	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2011	Cruze	Body	Body Control Module																																																												
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2011	Cruze	Body	Passenger Presence Module																																																												
J	2011	Cruze	Body	Instrument Cluster																																																												
J	2011	Cruze	Body	Trailer Interface Control Module																																																												
J	2011	Cruze	Body	Radio																																																											
J	2011	Cruze	Body	Multimedia Player Interface Module																																																											
J	2011	Cruze	Body	Mobile Telephone Control Module																																																											
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
J	2011	Cruze	Body	Keyless Entry Control Module																																																											
J	2011	Cruze	Body	Parking Assist Control Module																																																											
J	2011	Cruze	Body	Steering Column Lock Control Module																																																											
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																											
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2011	Other	Powertrain	Transmission Control Module 5 Speed																																																											
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2011	Other	Chassis	Tire Pressure Monitor																																																											
J	2011	Other	Body	Remote Function Actuation																																																											
J	2011	Other	Body	Supplemental Inflatable Restraint																																																											
J	2011	Other	Body	Supplemental Inflatable Restraint																																																											
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																												V															
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																												V															
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2012	Aveo	Powertrain	Fuel Pump Control Module																																																												
J	2012	Aveo	Powertrain	Fuel Injector Control Module																																																												
J	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Aveo	Chassis	Electric Power Steering Control Module																																																												
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Aveo	Body	Body Control Module Hatchback																																																												
J	2012	Aveo	Body	Body Control Module Sedan																																																												
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2012	Aveo	Body	Passenger Presence Module																																																												
J	2012	Aveo	Body	Instrument Cluster																																																												
J	2012	Aveo	Body	Radio																																																											
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																													V	V													
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
J	2012	Aveo	Body	Front Seat Heating Control Module																																																												
J	2012	Aveo	Body	Parking Assist Control Module																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																												
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																												V															
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																												V															
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2012	Cobalt	Chassis	Electronic Brake Control Module																																																												
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																												
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Cobalt	Body	Body Control Module																																																												
J	2012	Cobalt	Body	Passenger Presence Module																																																												
J	2012	Cobalt	Body	Instrument Cluster																																																												
J	2012	Cobalt	Body	Radio																																																											
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																													V	V													
J	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																												
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
J	2012	Cobalt	Body	Front Seat Heating Control Module																																																												
J	2012	Cobalt	Body	Parking Assist Control Module																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																												
J	2012	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Cruze	Body	Body Control Module Hatchback																																																												
J	2012	Cruze	Body	Body Control Module Sedan																																																												
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2012	Cruze	Body	Passenger Presence Module																																																												
J	2012	Cruze	Body	Instrument Cluster																																																												
J	2012	Cruze	Body	Trailer Interface Control Module																																																												
J	2012	Cruze	Body	Radio																																																											
J	2012	Cruze	Body	Multimedia Player Interface Module																																																											
J	2012	Cruze	Body	Mobile Telephone Control Module																																																											
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																														
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																															
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																															
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																															
J	2012	Cruze	Body	Keyless Entry Control Module																																																															
J	2012	Cruze	Body	Parking Assist Control Module																																																															
J	2012	Cruze	Body	Steering Column Lock Control Module																																																															
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																															
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																															
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																															
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																															
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																															
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																															
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																															
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																															
J	2012	Sonic (First Gen)	Body	Remote Function Actuation																																																															
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																															
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																															
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																															
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																															
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																															
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																												V																	
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																												V																	
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module																																																															
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																												V																	
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																												V																	
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module																																																															
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																												V																	
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																												V																	
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																															
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																															
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																															
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																															
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module Chassis Expansion CAN BUS																																																												
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module High Speed CAN Bus																																																											
J	2012	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																											
J	2012	Sonic (Second Gen)	Body	Body Control Module Sedan																																																											
J	2012	Sonic (Second Gen)	Body	Passenger Presence Module																																																											
J	2012	Sonic (Second Gen)	Body	Instrument Cluster																																																											
J	2012	Sonic (Second Gen)	Body	Radio																																																											
J	2012	Sonic (Second Gen)	Body	Telematic Vehicle Localization and Immobilization Control Module																																												V	V												
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																											
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																											
J	2012	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																											
J	2012	Sonic (Second Gen)	Body	Parking Assist Control Module																																																											
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																											V																
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																											V																
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
J	2013	Aveo	Powertrain	Fuel Pump Control Module																																																											
J	2013	Aveo	Powertrain	Fuel Injector Control Module																																																											
J	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
J	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2013	Aveo	Chassis	Electric Power Steering Control Module																																																											
J	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2013	Aveo	Body	Body Control Module Hatchback																																																											
J	2013	Aveo	Body	Body Control Module Sedan																																																											
J	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2013	Aveo	Body	Passenger Presence Module																																																											
J	2013	Aveo	Body	Instrument Cluster																																																											
J	2013	Aveo	Body	Radio																																																											
J	2013	Aveo	Body	Telematics Communication Interface Control Module																																																											
J	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
J	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
J	2013	Aveo	Body	Front Seat Heating Control Module																																																											
J	2013	Aveo	Body	Parking Assist Control Module																																																											
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																												V																
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																												V																
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																												V																
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																												V																
J	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2013	Cobalt	Chassis	Electronic Brake Control Module																																																											
J	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2013	Cobalt	Body	Body Control Module																																																											
J	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2013	Cobalt	Body	Instrument Cluster																																																											
J	2013	Cobalt	Body	Radio																																																										
J	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																											
J	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											
J	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
J	2013	Cobalt	Body	Front Seat Heating Control Module																																																											
J	2013	Cobalt	Body	Parking Assist Control Module																																																											
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																											
J	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																											V															
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																											V															
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																															V	V	V		V					
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																															V	V	V		V					
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2013	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Cruze	Body	Body Control Module Hatchback																																																										
J	2013	Cruze	Body	Body Control Module Sedan																																																										
J	2013	Cruze	Body	Body Control Module Station Wagon																																																										
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Cruze	Body	Passenger Presence Module																																																										
J	2013	Cruze	Body	Instrument Cluster																																																										
J	2013	Cruze	Body	Trailer Interface Control Module																																																										
J	2013	Cruze	Body	Radio																																																										
J	2013	Cruze	Body	Digital Radio Receiver Control Module																																																										
J	2013	Cruze	Body	Multimedia Player Interface Module																																																										
J	2013	Cruze	Body	Mobile Telephone Control Module																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
J	2013	Cruze	Body	Front Seat Heating Control Module																																																										
J	2013	Cruze	Body	Keyless Entry Control Module																																																										
J	2013	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Body	Steering Column Lock Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2013	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																											
J	2013	Sonic (First Gen)	Body	Remote Function Actuation																																																											
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																											
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																											
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																											
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																											V																
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																											V																
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Transmission Control Module																																																											
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																											
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																											V																
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																											V																
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Fuel Pump Control Module																																																											
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																											V																
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																											V																
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																											V																
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																											V																
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																											V																
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																											V																
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Fuel Pump Control Module																																																											
J	2013	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																											
J	2013	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2013	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2013	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																											
J	2013	Sonic (Second Gen)	Body	Body Control Module Sedan																																																											
J	2013	Sonic (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2013	Sonic (Second Gen)	Body	Passenger Presence Module																																																											
J	2013	Sonic (Second Gen)	Body	Instrument Cluster																																																											
J	2013	Sonic (Second Gen)	Body	Radio																																																											
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																											
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																													
J	2013	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																													
J	2013	Sonic (Second Gen)	Body	Parking Assist Control Module																																																													
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																													
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																													
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																													
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																													
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																													
J	2013	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																													
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																													
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																													
J	2013	Spin	Powertrain	1.8L LMD Transmission Control Module																																																													
J	2013	Spin	Chassis	Electronic Brake Control Module																																																													
J	2013	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2013	Spin	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2013	Spin	Body	Body Control Module																																																													
J	2013	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2013	Spin	Body	Instrument Cluster																																																													
J	2013	Spin	Body	Radio																																																												
J	2013	Spin	Body	HVAC Control Module Heater Only (C41)																																																													
J	2013	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2013	Spin	Body	HVAC Control Module Single Zone (C60)																																																													
J	2013	Spin	Body	Parking Assist Control Module																																																													
J	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																													
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																													
J	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																													
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																													
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																												V																
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																												V																
J	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																													
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																													
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																													
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
J	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																											V																
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																											V																
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																											V																
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																											V																
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
J	2014	Aveo	Powertrain	Chassis Control Module																																																													
J	2014	Aveo	Powertrain	Fuel Injector Control Module																																																												
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2014	Aveo	Chassis	Power Steering Control Module																																																												
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Aveo	Body	Body Control Module Hatchback																																																												
J	2014	Aveo	Body	Body Control Module Sedan																																																												
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Aveo	Body	Instrument Cluster																																																												
J	2014	Aveo	Body	Radio																																																												
J	2014	Aveo	Body	Telematics Communication Interface Control Module																																																												
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Aveo	Body	Front Seat Heating Control Module																																																												
J	2014	Aveo	Body	Keyless Entry Control Module																																																												
J	2014	Aveo	Body	Parking Assist Control Module																																																												
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																												
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																											V																
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																											V																
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																											V																
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																											V																
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
J	2014	Cobalt	Chassis	Electronic Brake Control Module																																																												
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Cobalt	Body	Body Control Module																																																												
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Cobalt	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2014	Cobalt	Body	Radio																																																												
J	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Cobalt	Body	Front Seat Heating Control Module																																																												
J	2014	Cobalt	Body	Parking Assist Control Module																																																												
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																														V														
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																														V														
J	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																															V	V	V		V					
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																															V	V	V		V					
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																			V					
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																												
J	2014	Cruze	Powertrain	Fuel Injector Control Module																																																												
J	2014	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2014	Cruze	Chassis	Power Steering Control Module																																																												
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Cruze	Body	Body Control Module Hatchback																																																												
J	2014	Cruze	Body	Body Control Module Sedan																																																												
J	2014	Cruze	Body	Body Control Module Station Wagon																																																												
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Cruze	Body	Passenger Presence Module																																																												
J	2014	Cruze	Body	Instrument Cluster																																																												
J	2014	Cruze	Body	Trailer Interface Control Module																																																												
J	2014	Cruze	Body	Radio																																																											
J	2014	Cruze	Body	Digital Radio Receiver Control Module																																																												
J	2014	Cruze	Body	Multimedia Player Interface Module																																																												
J	2014	Cruze	Body	Mobile Telephone Control Module																																																												
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																												
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																												
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																												
J	2014	Cruze	Body	Front Seat Heating Control Module																																																												
J	2014	Cruze	Body	Keyless Entry Control Module																																																												
J	2014	Cruze	Body	Right Side Object Detection Control Module																																																												
J	2014	Cruze	Body	Left Side Object Detection Control Module																																																												
J	2014	Cruze	Body	Parking Assist Control Module																																																												
J	2014	Cruze	Body	Steering Column Lock Control Module																																																												
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module																																																												
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																												V													
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																												V													
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2014	Sonic	Powertrain	1.4L LDD Chassis Control Module																																																												
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.4L LUJ Chassis Control Module																																																												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Chassis Control Module																																																												
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																												V															
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																												V															
J	2014	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(C) 1.6L LDE Chassis Control Module																																																												
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																												V															
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																												V															
J	2014	Sonic	Powertrain	1.6L LED Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																												V															
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																												V															
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																												V															
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																												V															
J	2014	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(H) 1.8L LUW Chassis Control Module																																																												
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																												V															
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																												V															
J	2014	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(G) 1.8L LWE Chassis Control Module																																																												
J	2014	Sonic	Powertrain	Fuel Injector Control Module																																																												
J	2014	Sonic	Chassis	Electronic Brake Control Module																																																												
J	2014	Sonic	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2014	Sonic	Chassis	Power Steering Control Module																																																												
J	2014	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Sonic	Body	Body Control Module Hatchback																																																												
J	2014	Sonic	Body	Body Control Module Sedan																																																												
J	2014	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Sonic	Body	Passenger Presence Module																																																												
J	2014	Sonic	Body	Instrument Cluster																																																												
J	2014	Sonic	Body	Radio																																																											
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2014	Sonic	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Sonic	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Sonic	Body	Front Seat Heating Control Module																																																												
J	2014	Sonic	Body	Parking Assist Control Module																																																												
J	2014	Sonic	Body	Frontview Camera Module																																																												
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																												
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																													
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																													
J	2014	Spin	Powertrain	1.5L L2B Transmission Control Module																																																													
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Automatic Transmission																																												V																
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Manual Transmission																																												V																
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																													
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																													
J	2014	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																													
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																												V																
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																												V																
J	2014	Spin	Powertrain	1.8L LMD Transmission Control Module																																																													
J	2014	Spin	Chassis	Electronic Brake Control Module																																																													
J	2014	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2014	Spin	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2014	Spin	Body	Body Control Module																																																													
J	2014	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2014	Spin	Body	Instrument Cluster																																																													
J	2014	Spin	Body	Radio																																																												
J	2014	Spin	Body	HVAC Control Module Heater Only (C41)																																																													
J	2014	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2014	Spin	Body	HVAC Control Module Single Zone (C60)																																																													
J	2014	Spin	Body	Parking Assist Control Module																																																													
J	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																													
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																													
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																													
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																													
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																													
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																													
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																													
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																													
J	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																													
J	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																													
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																													
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																													
J	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																													
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																												V																
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																												V																
J	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																													
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																													
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																													
J	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																													
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																													
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
J	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																													
J	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																													
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																													
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																													
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																											V																	
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																											V																	
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																													
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																											V																	
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																											V																	
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																													
J	2015	Aveo	Powertrain	Chassis Control Module																																																														
J	2015	Aveo	Powertrain	Fuel Injector Control Module																																																													
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																													
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																													
J	2015	Aveo	Chassis	Power Steering Control Module																																																													
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2015	Aveo	Body	Body Control Module Hatchback																																																													
J	2015	Aveo	Body	Body Control Module Sedan																																																													
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2015	Aveo	Body	Instrument Cluster																																																													
J	2015	Aveo	Body	Radio																																																												
J	2015	Aveo	Body	Telematics Communication Interface Control Module																																																													
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																													
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																													
J	2015	Aveo	Body	Front Seat Heating Control Module																																																													
J	2015	Aveo	Body	Keyless Entry Control Module																																																													
J	2015	Aveo	Body	Parking Assist Control Module																																																													
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																													
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																											V																	
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																											V																	
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																													
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																													
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																													
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																													
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																													
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																													
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																											V																	
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																											V																	
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																													
J	2015	Cobalt	Chassis	Electronic Brake Control Module																																																													
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2015	Cobalt	Body	Body Control Module																																																													
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2015	Cobalt	Body	Instrument Cluster																																																													
J	2015	Cobalt	Body	Radio																																																												
J	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																													
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
J	2015	Cobalt	Body	Front Seat Heating Control Module																																																												
J	2015	Cobalt	Body	Parking Assist Control Module																																																												
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																												
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																												
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																												
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																												
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
J	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																												
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																												
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																												
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																												
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																												
J	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																												
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																												
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																												
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																												
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																												
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
J	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																												V															
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																												V															
J	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																												
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																											
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																											
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																											
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
J	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																											
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																											
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																											
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																											
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																											
J	2015	Cruze	Powertrain	Fuel Injector Control Module																																																												
J	2015	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2015	Cruze	Chassis	Power Steering Control Module																																																												
J	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2015	Cruze	Body	Body Control Module Hatchback																																																												
J	2015	Cruze	Body	Body Control Module Sedan																																																												
J	2015	Cruze	Body	Body Control Module Station Wagon																																																												
J	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2015	Cruze	Body	Passenger Presence Module																																																												
J	2015	Cruze	Body	Instrument Cluster																																																												
J	2015	Cruze	Body	Trailer Interface Control Module																																																												
J	2015	Cruze	Body	Radio																																																												
J	2015	Cruze	Body	Digital Radio Receiver Control Module																																																												
J	2015	Cruze	Body	Multimedia Player Interface Module																																																												
J	2015	Cruze	Body	Mobile Telephone Control Module																																																												
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																												
J	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																												
J	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																												
J	2015	Cruze	Body	Front Seat Heating Control Module																																																												
J	2015	Cruze	Body	Keyless Entry Control Module																																																												
J	2015	Cruze	Body	Right Side Object Detection Control Module																																																												
J	2015	Cruze	Body	Left Side Object Detection Control Module																																																												
J	2015	Cruze	Body	Parking Assist Control Module																																																												
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																												V															
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																												V															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2015	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																													
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																														
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																														
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																														
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	1.6L LED Transmission Control Module																																																														
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																														
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																														
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																														
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																														
J	2015	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																														
J	2015	Sonic	Powertrain	Chassis Control Module																																																														
J	2015	Sonic	Powertrain	Fuel Injector Control Module																																																														
J	2015	Sonic	Chassis	Electronic Brake Control Module																																																														
J	2015	Sonic	Chassis	Power Steering Control Module																																																														
J	2015	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																														
J	2015	Sonic	Body	Body Control Module Hatchback																																																														
J	2015	Sonic	Body	Body Control Module Sedan																																																														
J	2015	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
J	2015	Sonic	Body	Passenger Presence Module																																																														
J	2015	Sonic	Body	Instrument Cluster																																																														
J	2015	Sonic	Body	Radio																																																														
J	2015	Sonic	Body	Telematics Communication Interface Control Module																																																														
J	2015	Sonic	Body	HVAC Control Module Heater Only (C41)																																																														
J	2015	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
J	2015	Sonic	Body	HVAC Control Module Single Zone (C60)																																																														
J	2015	Sonic	Body	Front Seat Heating Control Module																																																														
J	2015	Sonic	Body	Parking Assist Control Module																																																														
J	2015	Sonic	Body	Frontview Camera Module																																																														
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																														
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																														
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																														
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																														
J	2015	Spin	Powertrain	1.5L L2B Transmission Control Module																																																														
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																												V																
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																												V																
J	2015	Spin	Powertrain	1.8L LMD Transmission Control Module																																																												
J	2015	Spin	Chassis	Electronic Brake Control Module																																																												
J	2015	Spin	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2015	Spin	Body	Body Control Module																																																												
J	2015	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2015	Spin	Body	Instrument Cluster																																																												
J	2015	Spin	Body	Radio																																																												
J	2015	Spin	Body	Telematics Communication Interface Control Module																																																												
J	2015	Spin	Body	HVAC Control Module Heater Only (C41)																																																												
J	2015	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2015	Spin	Body	HVAC Control Module Single Zone (C60)																																																												
J	2015	Spin	Body	Front Seat Heating Control Module																																																												
J	2015	Spin	Body	Parking Assist Control Module																																																												
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
J	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
J	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																												V																
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																												V																
J	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																												V																
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																												V																
J	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
J	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
J	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2016	Aveo	Powertrain	Chassis Control Module																																																												
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																														
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																														
J	2016	Aveo	Chassis	Power Steering Control Module																																																														
J	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																														
J	2016	Aveo	Body	Body Control Module Hatchback																																																														
J	2016	Aveo	Body	Body Control Module Sedan																																																														
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
J	2016	Aveo	Body	Instrument Cluster																																																														
J	2016	Aveo	Body	Radio																																																														
J	2016	Aveo	Body	Telematics Communication Interface Control Module																																																														
J	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
J	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																														
J	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																														
J	2016	Aveo	Body	Front Seat Heating Control Module																																																														
J	2016	Aveo	Body	Parking Assist Control Module																																																														
J	2016	Aveo	Body	Keyless Entry Control Module																																																														
J	2016	Aveo	Body	Frontview Camera Module																																																														
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																														
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																														
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																														
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																														
J	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																														
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																														
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																														
J	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																														
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																														
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																														
J	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																														
J	2016	Cobalt	Chassis	Electronic Brake Control Module																																																														
J	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																														
J	2016	Cobalt	Body	Body Control Module																																																														
J	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
J	2016	Cobalt	Body	Instrument Cluster																																																														
J	2016	Cobalt	Body	Radio Other																																																														
J	2016	Cobalt	Body	Radio (IOB)																																																														
J	2016	Cobalt	Body	Radio (UF7)																																																														
J	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																														
J	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
J	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																														
J	2016	Cobalt	Body	Front Seat Heating Control Module																																																														
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
J	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																														
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																														
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																														
J	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																														
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																													
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																													
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																													
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																													
J	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																													
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																													
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																											V																	
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																											V																	
J	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																													
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																													
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																													
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
J	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																													
J	2016	Cruze	Powertrain	Fuel Injector Control Module																																																													
J	2016	Cruze	Powertrain	Chassis Control Module																																																													
J	2016	Cruze	Chassis	Electronic Brake Control Module																																																													
J	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2016	Cruze	Chassis	Power Steering Control Module																																																													
J	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2016	Cruze	Body	Body Control Module Hatchback																																																													
J	2016	Cruze	Body	Body Control Module Sedan																																																													
J	2016	Cruze	Body	Body Control Module Station Wagon																																																													
J	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2016	Cruze	Body	Passenger Presence Module																																																													
J	2016	Cruze	Body	Instrument Cluster																																																													
J	2016	Cruze	Body	Trailer Interface Control Module																																																													
J	2016	Cruze	Body	Radio Other																																																												
J	2016	Cruze	Body	Radio (UF7)																																																													
J	2016	Cruze	Body	Multimedia Player Interface Module																																																													
J	2016	Cruze	Body	Mobile Telephone Control Module																																																													
J	2016	Cruze	Body	Telematics Communication Interface Control Module																																																													
J	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
J	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																													
J	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																													
J	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																													
J	2016	Cruze	Body	Front Seat Heating Control Module																																																													
J	2016	Cruze	Body	Keyless Entry Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2016	Cruze	Body	Right Side Object Detection Control Module																																																														
J	2016	Cruze	Body	Left Side Object Detection Control Module																																																														
J	2016	Cruze	Body	Parking Assist Control Module																																																														
J	2016	Cruze	Body	Steering Column Lock Control Module																																																														
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																														
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																														
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																														
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																														
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																														
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																														
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																													V															
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																													V															
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module																																																														
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																													V															
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																													V															
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																														
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																													V															
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																													V															
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																														
J	2016	Sonic	Powertrain	Chassis Control Module																																																														
J	2016	Sonic	Powertrain	Fuel Injector Control Module																																																														
J	2016	Sonic	Chassis	Electronic Brake Control Module																																																														
J	2016	Sonic	Chassis	Power Steering Control Module																																																														
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																														
J	2016	Sonic	Body	Body Control Module Hatchback																																																														
J	2016	Sonic	Body	Body Control Module Sedan																																																														
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
J	2016	Sonic	Body	Passenger Presence Module																																																														
J	2016	Sonic	Body	Instrument Cluster																																																														
J	2016	Sonic	Body	Radio Other																																																													
J	2016	Sonic	Body	Radio (UF7)																																																														
J	2016	Sonic	Body	Radio (UH7)																																																														
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7																																																														
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																														
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Sonic	Body	Front Seat Heating Control Module																																																												
J	2016	Sonic	Body	Parking Assist Control Module																																																												
J	2016	Sonic	Body	Frontview Camera Module																																																												
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module																																																												
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																													V															
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																													V															
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module																																																												
J	2016	Spin	Chassis	Electronic Brake Control Module																																																												
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Spin	Body	Body Control Module																																																												
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Spin	Body	Instrument Cluster																																																												
J	2016	Spin	Body	Radio																																																												
J	2016	Spin	Body	Telematics Communication Interface Control Module																																																												
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)																																																												
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)																																																												
J	2016	Spin	Body	Front Seat Heating Control Module																																																												
J	2016	Spin	Body	Parking Assist Control Module																																																												
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																												
K	2006	ALL	Powertrain	Transmission Control Module																																																												
K	2006	ALL	Chassis	Electronic Brake Control Module																																																												
K	2006	ALL	Body	Remote Function Actuation																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																												
K	2007	ALL	Powertrain	Transmission Control Module																																																												
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module																																																												
K	2007	ALL	Chassis	Teves Electronic Brake Control Module																																																												
K	2007	ALL	Body	Remote Function Actuation																																																												
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																												
K	2008	ALL	Powertrain	Transmission Control Module																																																												
K	2008	ALL	Chassis	Electronic Brake Control Module																																																												
K	2008	ALL	Body	Remote Function Actuation																																																												
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2009	ALL	Powertrain	Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2009	ALL	Chassis	Electronic Brake Control Module																																																												
K	2009	ALL	Body	Remote Function Actuation																																																													
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2010	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2010	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2010	ALL	Powertrain	Transmission Control Module																																																												
K	2010	ALL	Chassis	Electronic Brake Control Module																																																												
K	2010	ALL	Body	Remote Function Actuation																																																												
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2011	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2011	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2011	ALL	Powertrain	Transmission Control Module																																																												
K	2011	ALL	Chassis	Electronic Brake Control Module																																																												
K	2011	ALL	Body	Remote Function Actuation																																																												
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2012	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2012	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2012	ALL	Powertrain	Transmission Control Module																																																												
K	2012	ALL	Chassis	Electronic Brake Control Module																																																												
K	2012	ALL	Body	Remote Function Actuation																																																												
K	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2013	Onix	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2013	Onix	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																															V													
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																															V													
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																															V													
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																															V													
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																												
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																												
K	2013	Onix	Powertrain	Transmission Control Module																																																												
K	2013	Onix	Powertrain	Transmission Control Module																																																												
K	2013	Onix	Chassis	Electronic Brake Control Module																																																												
K	2013	Onix	Chassis	Electronic Brake Control Module																																																												
K	2013	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2013	Onix	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2013	Onix	Body	Body Control Module																																																												
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2013	Onix	Body	Instrument Cluster																																																												
K	2013	Onix	Body	Radio																																																												
K	2013	Onix	Body	Parking Assist Control Module																																																												
K	2013	Onix	Body	Remote Function Actuation																																																												
K	2013	Prisma	Powertrain	Engine Control Module																																																												
K	2013	Prisma	Powertrain	Transmission Control Module																																																												
K	2013	Prisma	Chassis	Electronic Brake Control Module																																																												
K	2013	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2013	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2013	Prisma	Body	Body Control Module																																																												
K	2013	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2013	Prisma	Body	Instrument Cluster																																																												
K	2013	Prisma	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2013	Prisma	Body	Parking Assist Control Module																																																											
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																											V															
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																											V															
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																											V															
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																											V															
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																								
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module																																																								
K	2014	Onix	Chassis	Electronic Brake Control Module																																																								
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2014	Onix	Body	Body Control Module																																																								
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2014	Onix	Body	Instrument Cluster																																																								
K	2014	Onix	Body	Radio																																																								
K	2014	Onix	Body	Parking Assist Control Module																																																								
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																											V															
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																											V															
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module																																																								
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																											V															
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																											V															
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																								
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																								
K	2014	Prisma	Chassis	Electronic Brake Control Module																																																								
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2014	Prisma	Body	Body Control Module																																																								
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2014	Prisma	Body	Instrument Cluster																																																								
K	2014	Prisma	Body	Radio																																																								
K	2014	Prisma	Body	Parking Assist Control Module																																																								
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																											V															
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																											V															
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																											V															
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																											V															
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																								
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module																																																								
K	2015	Onix	Chassis	Electronic Brake Control Module																																																								
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2015	Onix	Body	Body Control Module																																																								
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2015	Onix	Body	Instrument Cluster																																																								
K	2015	Onix	Body	Radio																																																								
K	2015	Onix	Body	Parking Assist Control Module																																																								
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																											V															
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																											V															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																										V														
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																										V														
K	2015	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																								
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2015	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																								
K	2015	Prisma	Chassis	Electronic Brake Control Module																																																								
K	2015	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2015	Prisma	Body	Body Control Module																																																								
K	2015	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2015	Prisma	Body	Instrument Cluster																																																								
K	2015	Prisma	Body	Radio																																																								
K	2015	Prisma	Body	Parking Assist Control Module																																																								
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																										V														
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																										V														
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																										V														
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																										V														
K	2016	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																								
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2016	Onix	Powertrain	1.4L LKK Transmission Control Module																																																								
K	2016	Onix	Chassis	Electronic Brake Control Module																																																								
K	2016	Onix	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2016	Onix	Body	Body Control Module																																																								
K	2016	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2016	Onix	Body	Instrument Cluster																																																								
K	2016	Onix	Body	Radio																																																								
K	2016	Onix	Body	Parking Assist Control Module																																																								
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																										V														
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																										V														
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																										V														
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																										V														
K	2016	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																								
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2016	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																								
K	2016	Prisma	Chassis	Electronic Brake Control Module																																																								
K	2016	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2016	Prisma	Body	Body Control Module																																																								
K	2016	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2016	Prisma	Body	Instrument Cluster																																																								
K	2016	Prisma	Body	Radio																																																								
K	2016	Prisma	Body	HVAC Control Module																																																								
K	2016	Prisma	Body	Front Seat Heating Control Module																																																								
K	2016	Prisma	Body	Parking Assist Control Module																																																								
L	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
L	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
L	2004	ALL	Powertrain	Transmission Control Module																																																								
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																								
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																								
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2004	ALL	Body	ISU																																																										
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2005	ALL	Powertrain	Transmission Control Module																																																										
L	2005	ALL	Chassis	Anti-lock Brake System																																																										
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2005	ALL	Body	ISU																																																										
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																										
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																										
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2006	ALL	Body	ISU																																																										
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																										
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																										
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector																																																										
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module																																																										
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Body	ISU																																																										
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																										
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																										
L	2008	ALL	Chassis	Electronic Brake Control Module																																											V															
L	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2008	ALL	Body	ISU																																																										
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																										
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																										
L	2009	ALL	Chassis	Electronic Brake Control Module																																											V															
L	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2009	ALL	Body	ISU																																																										
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																										
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																										
L	2010	ALL	Chassis	Electronic Brake Control Module																																											V															
L	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2010	ALL	Body	ISU																																																										
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																												
L	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																													
L	2011	ALL	Chassis	Electronic Brake Control Module																																									V																			
L	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
L	2011	ALL	Body	ISU																																																												
M	2004	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2004	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2004	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2004	ALL	Chassis	Anti-lock Brake System																																																												
M	2004	ALL	Body	Remote Function Actuation																																																												
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2005	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2005	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2005	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2005	ALL	Chassis	Anti-lock Brake System																																																												
M	2005	ALL	Body	Remote Function Actuation																																																												
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2006	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2006	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2006	ALL	Chassis	Anti-lock Brake System																																																												
M	2006	ALL	Body	Remote Function Actuation																																																												
M	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2007	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2007	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2007	ALL	Chassis	Anti-lock Brake System																																																												
M	2007	ALL	Body	Remote Function Actuation																																																												
M	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2008	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2008	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2008	ALL	Chassis	Anti-lock Brake System																																																												
M	2008	ALL	Body	Remote Function Actuation																																																												
M	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
M	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
M	2009	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																												
M	2009	ALL	Chassis	Anti-lock Brake System																																																												
M	2009	ALL	Body	Remote Function Actuation																																																												
M	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
M	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
M	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
M	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
M	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
M	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
M	2010	Spark	Powertrain	Transmission Control Module																																																												
M	2010	Spark	Chassis	Electronic Brake Control Module																																																												
M	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
M	2010	Spark	Chassis	Electric Power Steering Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
M	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																														
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2010	Spark	Body	Passenger Presence Module																																																														
M	2010	Spark	Body	Instrument Cluster																																																														
M	2011	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																														
M	2011	Caprice	Powertrain	Transmission Control Module																																																														
M	2011	Caprice	Powertrain	Fuel Pump Control Module																																																														
M	2011	Caprice	Chassis	Electronic Brake Control Module																																																														
M	2011	Caprice	Body	Body Control Module																																																														
M	2011	Caprice	Body	HVAC Control Module																																																														
M	2011	Caprice	Body	Instrument Panel Cluster																																																														
M	2011	Caprice	Body	Passenger Presence System																																																														
M	2011	Caprice	Body	Radio																																																														
M	2011	Caprice	Body	Remote Control Door Lock Receiver																																																														
M	2011	Caprice	Body	Supplemental Inflatable Restraint																																																														
M	2011	Caprice	Body	Theft Deterrent Module																																																														
M	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																														
M	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																														
M	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																														
M	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																														
M	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																														
M	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																														
M	2011	Spark	Powertrain	Transmission Control Module																																																														
M	2011	Spark	Chassis	Electronic Brake Control Module																																																														
M	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																														
M	2011	Spark	Chassis	Electric Power Steering Control Module																																																														
M	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																														
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2011	Spark	Body	Passenger Presence Module																																																														
M	2011	Spark	Body	Instrument Cluster																																																														
M	2012	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																														
M	2012	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																														
M	2012	Caprice	Powertrain	Transmission Control Module																																																														
M	2012	Caprice	Powertrain	Fuel Pump Control Module																																																														
M	2012	Caprice	Chassis	Electronic Brake Control Module																																																														
M	2012	Caprice	Body	Body Control Module																																																														
M	2012	Caprice	Body	HVAC Control Module																																																														
M	2012	Caprice	Body	Instrument Panel Cluster																																																														
M	2012	Caprice	Body	Passenger Presence System																																																														
M	2012	Caprice	Body	Radio																																																														
M	2012	Caprice	Body	Remote Control Door Lock Receiver																																																														
M	2012	Caprice	Body	Supplemental Inflatable Restraint																																																														
M	2012	Caprice	Body	Theft Deterrent Module																																																														
M	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																														
M	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																														
M	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																														
M	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																														
M	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																														
M	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
M	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																														
M	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																														
M	2012	Spark	Powertrain	Transmission Control Module																																																														
M	2012	Spark	Chassis	Electronic Brake Control Module																																																													
M	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																													
M	2012	Spark	Chassis	Electric Power Steering Control Module																																																													
M	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																													
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2012	Spark	Body	Passenger Presence Module																																																													
M	2012	Spark	Body	Instrument Cluster																																																													
M	2013	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																													
M	2013	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																													
M	2013	Caprice	Powertrain	Transmission Control Module																																																													
M	2013	Caprice	Powertrain	Fuel Pump Control Module																																																													
M	2013	Caprice	Chassis	Electronic Brake Control Module																																																													
M	2013	Caprice	Body	Body Control Module																																																													
M	2013	Caprice	Body	HVAC Control Module																																																													
M	2013	Caprice	Body	Instrument Panel Cluster																																																													
M	2013	Caprice	Body	Passenger Presence System																																																													
M	2013	Caprice	Body	Radio																																																													
M	2013	Caprice	Body	Remote Control Door Lock Receiver																																																													
M	2013	Caprice	Body	Supplemental Inflatable Restraint																																																													
M	2013	Caprice	Body	Theft Deterrent Module																																																													
M	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																													
M	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																													
M	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																													
M	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																													
M	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																													
M	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																													
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																											V																	
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																											V																	
M	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																													
M	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																													
M	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																													
M	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																													
M	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																													
M	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																													
M	2013	Spark	Powertrain	Fuel Injector Control Module																																																													
M	2013	Spark	Chassis	Electronic Brake Control Module																																																													
M	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																													
M	2013	Spark	Chassis	Power Steering Control Module																																																													
M	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																													
M	2013	Spark	Body	Body Control Module																																																													
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2013	Spark	Body	Passenger Presence Module																																																													
M	2013	Spark	Body	Instrument Cluster																																																													
M	2013	Spark	Body	Radio																																																												
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																												
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
M	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
M	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
M	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
M	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																											
M	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
M	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																												V														
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																												V														
M	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																											
M	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
M	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																												V														
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																												V														
M	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
M	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
M	2014	Spark	Powertrain	Fuel Injector Control Module																																																											
M	2014	Spark	Chassis	Electronic Brake Control Module																																																											
M	2014	Spark	Chassis	Electronic Brake Control Module																																																											
M	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
M	2014	Spark	Chassis	Power Steering Control Module																																																											
M	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
M	2014	Spark	Body	Body Control Module																																																											
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2014	Spark	Body	Passenger Presence Module																																																											
M	2014	Spark	Body	Instrument Cluster																																																											
M	2014	Spark	Body	Radio																																																											
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
M	2014	Spark	Body	Keyless Entry Control Module																																																											
M	2014	Spark EV	Powertrain	Engine Control Module																																																											
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V																																																										
M	2014	Spark EV	Powertrain	Drive Motor Control Module																																																											
M	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
M	2014	Spark EV	Chassis	Electronic Brake Control Module		V	V																																																								
M	2014	Spark EV	Chassis	Parking Brake Control Module																																																											
M	2014	Spark EV	Chassis	Power Steering Control Module																																																											
M	2014	Spark EV	Body	Body Control Module																																																											
M	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
M	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2014	Spark EV	Body	Passenger Presence Module																																																											
M	2014	Spark EV	Body	Instrument Cluster																																																											
M	2014	Spark EV	Body	Radio																																																										
M	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																											
M	2014	Spark EV	Body	HVAC Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
M	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																											
M	2014	Spark EV	Body	Coolant Heater Control Module																																																												
M	2014	Spark EV	Body	Keyless Entry Control Module																																																												
M	2014	Spark EV	Body	Battery Charger Control Module																																																												
M	2014	Spark EV	Body	DC Charging Control Module																																																												
M	2014	Spark EV	Body	Battery Energy Control Module				V	V	V	V																																																					
M	2015	Matiz	Powertrain	1.0L LA2 Engine Control Module																																																												
M	2015	Matiz	Chassis	Electronic Brake Control Module																																																												
M	2015	Matiz	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2015	Matiz	Body	Keyless Entry Control Module																																																												
M	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																												
M	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																												
M	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																												
M	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
M	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																												
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																												
M	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																												
M	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
M	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
M	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																												
M	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																												
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
M	2015	Spark	Powertrain	Fuel Injector Control Module																																																												
M	2015	Spark	Chassis	Electronic Brake Control Module																																																												
M	2015	Spark	Chassis	Electronic Brake Control Module																																																												
M	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
M	2015	Spark	Chassis	Power Steering Control Module																																																												
M	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
M	2015	Spark	Body	Body Control Module																																																												
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2015	Spark	Body	Passenger Presence Module																																																												
M	2015	Spark	Body	Instrument Cluster																																																												
M	2015	Spark	Body	Instrument Cluster																																																												
M	2015	Spark	Body	Tire Pressure Indicator Module																																																												
M	2015	Spark	Body	Radio																																																												
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																												
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																												
M	2015	Spark	Body	Keyless Entry Control Module																																																												
M	2015	Spark EV	Powertrain	Engine Control Module																																																												
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																												
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V																																																											
M	2015	Spark EV	Powertrain	Drive Motor Control Module																																																												
M	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
M	2015	Spark EV	Chassis	Electronic Brake Control Module		V	V																																																									
M	2015	Spark EV	Chassis	Parking Brake Control Module																																																													
M	2015	Spark EV	Chassis	Power Steering Control Module																																																													
M	2015	Spark EV	Body	Body Control Module																																																													
M	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																													
M	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2015	Spark EV	Body	Passenger Presence Module																																																													
M	2015	Spark EV	Body	Instrument Cluster																																																													
M	2015	Spark EV	Body	Radio																																																												
M	2015	Spark EV	Body	HVAC Control Module																																																													
M	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																													
M	2015	Spark EV	Body	Coolant Heater Control Module																																																													
M	2015	Spark EV	Body	Keyless Entry Control Module																																																													
M	2015	Spark EV	Body	Battery Charger Control Module																																																													
M	2015	Spark EV	Body	DC Charging Control Module																																																													
M	2015	Spark EV	Body	Battery Energy Control Module				V	V	V	V																																																					
M	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																													
M	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																													
M	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																													
M	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																													
M	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																													
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																													
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																													
M	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																													
M	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																													
M	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																													
M	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																													
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																													
M	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																													
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																													
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																												V																
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																												V																
M	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																													
M	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																													
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																													
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																													
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																													
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																													
M	2016	Spark	Powertrain	Fuel Injector Control Module																																																													
M	2016	Spark	Chassis	Electronic Brake Control Module																																																													
M	2016	Spark	Chassis	Electronic Brake Control Module																																																													
M	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																													
M	2016	Spark	Chassis	Power Steering Control Module																																																													
M	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																													
M	2016	Spark	Body	Body Control Module																																																													
M	2016	Spark	Body	Body Control Module																																																													
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2016	Spark	Body	Instrument Cluster																																																													
M	2016	Spark	Body	Instrument Cluster																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
M	2016	Spark	Body	Radio																																																										
M	2016	Spark	Body	Telematics Communication Interface Control Module																																																										
M	2016	Spark	Body	Keyless Entry Control Module																																																										
M	2016	Spark EV	Powertrain	Engine Control Module																																																										
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2	V							V																																																		
M	2016	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
M	2016	Spark EV	Chassis	Electronic Brake Control Module		V	V																																																							
M	2016	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2016	Spark EV	Chassis	Power Steering Control Module																																																										
M	2016	Spark EV	Body	Body Control Module																																																										
M	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark EV	Body	Passenger Presence Module																																																										
M	2016	Spark EV	Body	Instrument Cluster																																																										
M	2016	Spark EV	Body	Radio																																																										
M	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
M	2016	Spark EV	Body	HVAC Control Module																																																										
M	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2016	Spark EV	Body	Coolant Heater Control Module																																																										
M	2016	Spark EV	Body	Keyless Entry Control Module																																																										
M	2016	Spark EV	Body	Frontview Camera Module																																																										
M	2016	Spark EV	Body	Battery Charger Control Module																																																										
M	2016	Spark EV	Body	DC Charging Control Module																																																										
M	2016	Spark EV	Body	Battery Energy Control Module				V	V	V	V																																																			
N	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
N	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2004	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
N	2004	Optra	Body	Remote Function Actuation																																																										
N	2004	Optra	Body	Supplemental Inflatable Restraint																																																										
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
N	2004	Classic	Chassis	Anti-lock Brake System																																																										
N	2004	Classic	Body	Body Control Module										V																																																
N	2004	Classic	Body	Radio																																																										
N	2004	Classic	Body	Remote Function Actuation																																																										
N	2004	Classic	Body	Supplemental Inflatable Restraint																																																										
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																										
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Transmission Control Module																																																										
N	2004	Alero (Export)	Chassis	Anti-lock Brake System																																																										
N	2004	Alero (Export)	Body	Body Control Module										V																																																
N	2004	Alero (Export)	Body	Instrument Panel Cluster																																																										
N	2004	Alero (Export)	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
N	2004	Alero (Export)	Body	Supplemental Inflatable Restraint																																																												
N	2004	Alero (Export)	Body	Vehicle Theft Deterrent																																																												
N	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
N	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
N	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																												
N	2005	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
N	2005	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
N	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																												
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																												
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																												
N	2005	Optra	Body	Remote Function Actuation																																																												
N	2005	Optra	Body	Supplemental Inflatable Restraint																																																												
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
N	2005	Classic	Chassis	Anti-lock Brake System																																																												
N	2005	Classic	Body	Body Control Module										V																																																	
N	2005	Classic	Body	Radio																																																												
N	2005	Classic	Body	Remote Function Actuation																																																												
N	2005	Classic	Body	Supplemental Inflatable Restraint																																																												
N	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
N	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
N	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
N	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																												
N	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
N	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
N	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																												
N	2006	ALL	Body	Remote Function Actuation																																																												
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
N	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
N	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
N	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																												
N	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
N	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
N	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
N	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																												
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																												
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																												
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																												
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																												
N	2007	ALL	Chassis	Tire Pressure Monitor																																																												
N	2007	ALL	Body	Remote Function Actuation																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
N	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
N	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																													
N	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																													
N	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																													
N	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																													
N	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																													
N	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																																																													
N	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																													
N	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																													
N	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																													
N	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																													
N	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																													
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																													
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																													
N	2008	ALL	Chassis	Tire Pressure Monitor																																																													
N	2008	ALL	Body	Remote Function Actuation																																																													
N	2008	ALL	Body	Supplemental Inflatable Restraint																																																													
N	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
N	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																													
N	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																													
N	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																													
N	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																													
N	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																													
N	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																													
N	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																													
N	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																													
N	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																													
N	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																													
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																													
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																													
N	2009	ALL	Chassis	Tire Pressure Monitor																																																													
N	2009	ALL	Body	Remote Function Actuation																																																													
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																													
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																													
N	2010	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
N	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																													
N	2010	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																													
N	2010	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																													
N	2010	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																													
N	2010	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
N	2010	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																													
N	2010	ALL	Powertrain	Transmission Control Module 5 Speed																																																													
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																												
N	2010	ALL	Chassis	Tire Pressure Monitor																																																													
N	2010	ALL	Body	Remote Function Actuation																																																													
N	2010	ALL	Body	Remote Function Actuation																																																													
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																													
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																													
N	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
N	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																														
N	2011	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																															
N	2011	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																															
N	2011	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																															
N	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
N	2011	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																															
N	2011	ALL	Powertrain	Transmission Control Module 5 Speed																																																															
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																															
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																															
N	2011	ALL	Chassis	Tire Pressure Monitor																																																															
N	2011	ALL	Body	Remote Function Actuation																																																															
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2012	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
N	2012	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																															
N	2012	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																															
N	2012	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																															
N	2012	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
N	2012	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																															
N	2012	ALL	Powertrain	Transmission Control Module 5 Speed																																																															
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																															
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																															
N	2012	ALL	Chassis	Tire Pressure Monitor																																																															
N	2012	ALL	Body	Remote Function Actuation																																																															
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2013	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
N	2013	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																															
N	2013	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																															
N	2013	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																															
N	2013	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
N	2013	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																															
N	2013	ALL	Powertrain	Transmission Control Module 5 Speed																																																															
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																															
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																															
N	2013	ALL	Chassis	Tire Pressure Monitor																																																															
N	2013	ALL	Body	Remote Function Actuation																																																															
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																															
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																															
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																															
N	2014	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																															
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																															
N	2014	Caprice	Powertrain	(2) 6.0L L77 Chassis Control Module																																																															
N	2014	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																															
N	2014	Caprice	Chassis	Electronic Brake Control Module																																																															
N	2014	Caprice	Chassis	Parking Brake Control Module																																																															
N	2014	Caprice	Chassis	Power Steering Control Module																																																															
N	2014	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																															
N	2014	Caprice	Body	Body Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
N	2014	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2014	Caprice	Body	Passenger Presence Module																																																													
N	2014	Caprice	Body	Instrument Cluster																																																												
N	2014	Caprice	Body	Radio Controls																																																												
N	2014	Caprice	Body	HVAC Controls																																																												
N	2014	Caprice	Body	Headlamp Control Module																																																												
N	2014	Caprice	Body	Trailer Interface Control Module																																																												
N	2014	Caprice	Body	Radio																																																												
N	2014	Caprice	Body	HVAC Control Module																																																												
N	2014	Caprice	Body	Parking Assist Control Module																																																												
N	2014	Caprice	Body	Frontview Camera Module																																																												
N	2014	Caprice	Body	Steering Column Lock Control Module																																																												
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
N	2015	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																												
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																												
N	2015	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																												
N	2015	Caprice	Powertrain	Fuel Injector Control Module																																																												
N	2015	Caprice	Chassis	Electronic Brake Control Module																																																												
N	2015	Caprice	Chassis	Parking Brake Control Module																																																												
N	2015	Caprice	Chassis	Power Steering Control Module																																																												
N	2015	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2015	Caprice	Chassis	Suspension Control Module																																																												
N	2015	Caprice	Body	Body Control Module																																																												
N	2015	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2015	Caprice	Body	Passenger Presence Module																																																												
N	2015	Caprice	Body	Instrument Cluster																																																												
N	2015	Caprice	Body	Head-Up Display Module																																																												
N	2015	Caprice	Body	Radio Controls																																																												
N	2015	Caprice	Body	HVAC Controls																																																												
N	2015	Caprice	Body	Headlamp Control Module																																																												
N	2015	Caprice	Body	Trailer Interface Control Module																																																												
N	2015	Caprice	Body	Radio																																																												
N	2015	Caprice	Body	Telematics Communication Interface Control Module																																																												
N	2015	Caprice	Body	HVAC Control Module																																																												
N	2015	Caprice	Body	Right Side Object Detection Control Module																																																												
N	2015	Caprice	Body	Left Side Object Detection Control Module																																																												
N	2015	Caprice	Body	Parking Assist Control Module																																																												
N	2015	Caprice	Body	Frontview Camera Module																																																												
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
N	2016	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																												
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																												
N	2016	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																												
N	2016	Caprice	Powertrain	Fuel Injector Control Module																																																												
N	2016	Caprice	Chassis	Electronic Brake Control Module																																																												
N	2016	Caprice	Chassis	Parking Brake Control Module																																																												
N	2016	Caprice	Chassis	Power Steering Control Module																																																												
N	2016	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
N	2016	Caprice	Chassis	Suspension Control Module																																																												
N	2016	Caprice	Body	Body Control Module																																																												
N	2016	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2016	Caprice	Body	Passenger Presence Module																																																												
N	2016	Caprice	Body	Instrument Cluster																																																												
N	2016	Caprice	Body	Head-Up Display Module																																																												
N	2016	Caprice	Body	Radio Controls																																																												
N	2016	Caprice	Body	HVAC Controls																																																												
N	2016	Caprice	Body	Trailer Interface Control Module																																																												
N	2016	Caprice	Body	Radio																																																												
N	2016	Caprice	Body	Telematics Communication Interface Control Module																																																												
N	2016	Caprice	Body	HVAC Control Module																																																												
N	2016	Caprice	Body	Seat Memory Control Module - Driver																																																												
N	2016	Caprice	Body	Right Side Object Detection Control Module																																																												
N	2016	Caprice	Body	Left Side Object Detection Control Module																																																												
N	2016	Caprice	Body	Parking Assist Control Module																																																												
N	2016	Caprice	Body	Frontview Camera Module																																																												
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																												
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																												
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																												
P	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																												
P	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																												
P	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																												
P	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																												
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																												
P	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																												
P	2010	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2010	Cruze	Body	Body Control Module																																																												
P	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2010	Cruze	Body	Passenger Presence Module																																																												
P	2010	Cruze	Body	Instrument Cluster																																																												
P	2010	Cruze	Body	Trailer Interface Control Module																																																												
P	2010	Cruze	Body	Radio																																																												
P	2010	Cruze	Body	Multimedia Player Interface Module																																																												
P	2010	Cruze	Body	Mobile Telephone Control Module																																																												
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
P	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																												
P	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																												
P	2010	Cruze	Body	Keyless Entry Control Module																																																												
P	2010	Cruze	Body	Parking Assist Control Module																																																												
P	2010	Cruze	Body	Steering Column Lock Control Module																																																												
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																												
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																												
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																													
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																													
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																													
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																													
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																													
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																													
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																													
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																													
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																													
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																													
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																													
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																													
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																													
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																													
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																													
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																													
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																													
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																													
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																													
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																													
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																													
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																V	V	V		V			
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																V	V	V		V			
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																													
P	2011	Cruze	Chassis	Electronic Brake Control Module																																																													
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																													
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
P	2011	Cruze	Body	Body Control Module																																																													
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
P	2011	Cruze	Body	Passenger Presence Module																																																													
P	2011	Cruze	Body	Instrument Cluster																																																													
P	2011	Cruze	Body	Trailer Interface Control Module																																																													
P	2011	Cruze	Body	Radio																																																												
P	2011	Cruze	Body	Multimedia Player Interface Module																																																													
P	2011	Cruze	Body	Mobile Telephone Control Module																																																													
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																													
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																													
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																													
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																													
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																													
P	2011	Cruze	Body	Keyless Entry Control Module																																																													
P	2011	Cruze	Body	Parking Assist Control Module																																																													
P	2011	Cruze	Body	Steering Column Lock Control Module																																																													
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																													
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																													
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																													
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																													
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																													
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
P	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																														
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																														
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																														
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																														
P	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																														
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																														
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																														
P	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																														
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																														
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																														
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																														
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																														
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																														
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																														
P	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																														
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																														
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																														
P	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																														
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																														
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																														
P	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																														
P	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																														
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																														
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																														
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																														
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																														
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																														
P	2012	Cruze	Chassis	Electronic Brake Control Module																																																														
P	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																														
P	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																														
P	2012	Cruze	Body	Body Control Module Hatchback																																																														
P	2012	Cruze	Body	Body Control Module Sedan																																																														
P	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
P	2012	Cruze	Body	Passenger Presence Module																																																														
P	2012	Cruze	Body	Instrument Cluster																																																														
P	2012	Cruze	Body	Trailer Interface Control Module																																																														
P	2012	Cruze	Body	Radio																																																														
P	2012	Cruze	Body	Multimedia Player Interface Module																																																														
P	2012	Cruze	Body	Mobile Telephone Control Module																																																														
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																														
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																														
P	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																														
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																														
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																														
P	2012	Cruze	Body	Keyless Entry Control Module																																																														
P	2012	Cruze	Body	Parking Assist Control Module																																																														
P	2012	Cruze	Body	Steering Column Lock Control Module																																																														
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																														
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																														
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																													
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																													
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																													
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																													
P	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																													
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																											V																	
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																											V																	
P	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																													
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
P	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																													
P	2013	Cruze	Chassis	Electronic Brake Control Module																																																													
P	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																													
P	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
P	2013	Cruze	Body	Body Control Module Hatchback																																																													
P	2013	Cruze	Body	Body Control Module Sedan																																																													
P	2013	Cruze	Body	Body Control Module Station Wagon																																																													
P	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
P	2013	Cruze	Body	Passenger Presence Module																																																													
P	2013	Cruze	Body	Instrument Cluster																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
P	2013	Cruze	Body	Trailer Interface Control Module																																																												
P	2013	Cruze	Body	Radio																																																												
P	2013	Cruze	Body	Digital Radio Receiver Control Module																																																												
P	2013	Cruze	Body	Multimedia Player Interface Module																																																												
P	2013	Cruze	Body	Mobile Telephone Control Module																																																												
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																												
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																												
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																												
P	2013	Cruze	Body	Front Seat Heating Control Module																																																												
P	2013	Cruze	Body	Keyless Entry Control Module																																																												
P	2013	Cruze	Body	Right Side Object Detection Control Module																																																												
P	2013	Cruze	Body	Left Side Object Detection Control Module																																																												
P	2013	Cruze	Body	Parking Assist Control Module																																																												
P	2013	Cruze	Body	Steering Column Lock Control Module																																																												
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																												
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																												
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																												
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																												
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																												
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																												
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																												
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																											V														
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																											V														
P	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																														V	V	V		V						
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																														V	V	V		V						
P	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																		V						
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																								
P	2014	Cruze	Powertrain	Fuel Injector Control Module																																																								
P	2014	Cruze	Chassis	Electronic Brake Control Module																																																								
P	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2014	Cruze	Chassis	Power Steering Control Module																																																								
P	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2014	Cruze	Body	Body Control Module Hatchback																																																								
P	2014	Cruze	Body	Body Control Module Sedan																																																								
P	2014	Cruze	Body	Body Control Module Station Wagon																																																								
P	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2014	Cruze	Body	Passenger Presence Module																																																								
P	2014	Cruze	Body	Instrument Cluster																																																								
P	2014	Cruze	Body	Trailer Interface Control Module																																																								
P	2014	Cruze	Body	Radio																																																								
P	2014	Cruze	Body	Digital Radio Receiver Control Module																																																								
P	2014	Cruze	Body	Multimedia Player Interface Module																																																								
P	2014	Cruze	Body	Mobile Telephone Control Module																																																								
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
P	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																								
P	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																								
P	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																								
P	2014	Cruze	Body	Front Seat Heating Control Module																																																								
P	2014	Cruze	Body	Keyless Entry Control Module																																																								
P	2014	Cruze	Body	Right Side Object Detection Control Module																																																								
P	2014	Cruze	Body	Left Side Object Detection Control Module																																																								
P	2014	Cruze	Body	Parking Assist Control Module																																																								
P	2014	Cruze	Body	Steering Column Lock Control Module																																																								

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																											V														
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																											V														
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																											V														
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																											V														
P	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																												
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																													
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																															V	V	V		V						
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																															V	V	V		V						
P	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																			V						
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																												
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																												
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																												
P	2015	Cruze	Powertrain	Fuel Injector Control Module																																																													
P	2015	Cruze	Chassis	Electronic Brake Control Module																																																													
P	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																													
P	2015	Cruze	Chassis	Power Steering Control Module																																																													
P	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
P	2015	Cruze	Body	Body Control Module Hatchback																																																													
P	2015	Cruze	Body	Body Control Module Sedan																																																													
P	2015	Cruze	Body	Body Control Module Station Wagon																																																													
P	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
P	2015	Cruze	Body	Passenger Presence Module																																																													
P	2015	Cruze	Body	Instrument Cluster																																																													
P	2015	Cruze	Body	Trailer Interface Control Module																																																													
P	2015	Cruze	Body	Radio																																																													
P	2015	Cruze	Body	Digital Radio Receiver Control Module																																																													
P	2015	Cruze	Body	Multimedia Player Interface Module																																																													
P	2015	Cruze	Body	Mobile Telephone Control Module																																																													
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																													
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																													
P	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																													
P	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																													
P	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																													
P	2015	Cruze	Body	Front Seat Heating Control Module																																																													
P	2015	Cruze	Body	Keyless Entry Control Module																																																													
P	2015	Cruze	Body	Right Side Object Detection Control Module																																																													
P	2015	Cruze	Body	Left Side Object Detection Control Module																																																													
P	2015	Cruze	Body	Parking Assist Control Module																																																													
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
P	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																													
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
P	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																													
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																													
P	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																													
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																													
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																											
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																											V																
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																											V																
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																															V	V	V		V				
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																															V	V	V		V				
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2016	Cruze	Powertrain	Fuel Injector Control Module																																																												
P	2016	Cruze	Powertrain	Chassis Control Module																																																												
P	2016	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2016	Cruze	Chassis	Power Steering Control Module																																																												
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2016	Cruze	Body	Body Control Module Hatchback																																																												
P	2016	Cruze	Body	Body Control Module Sedan																																																												
P	2016	Cruze	Body	Body Control Module Station Wagon																																																												
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2016	Cruze	Body	Passenger Presence Module																																																												
P	2016	Cruze	Body	Instrument Cluster																																																												
P	2016	Cruze	Body	Trailer Interface Control Module																																																												
P	2016	Cruze	Body	Radio Other																																																												
P	2016	Cruze	Body	Radio (UF7)																																																												
P	2016	Cruze	Body	Multimedia Player Interface Module																																																												
P	2016	Cruze	Body	Mobile Telephone Control Module																																																												
P	2016	Cruze	Body	Telematics Communication Interface Control Module																																																												
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																												
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																												
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																												
P	2016	Cruze	Body	Front Seat Heating Control Module																																																												
P	2016	Cruze	Body	Keyless Entry Control Module																																																												
P	2016	Cruze	Body	Right Side Object Detection Control Module																																																												
P	2016	Cruze	Body	Left Side Object Detection Control Module																																																												
P	2016	Cruze	Body	Parking Assist Control Module																																																												
P	2016	Cruze	Body	Steering Column Lock Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2011	Volt	Powertrain	Engine Control Module																																																													
R	2011	Volt	Powertrain	Trasmission Control Module																																																													
R	2011	Volt	Powertrain	Fuel Pump Control Module																																																													
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module																																																													
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module 2	V																																																												
R	2011	Volt	Powertrain	Drive Motor Control Module 1																																																													
R	2011	Volt	Powertrain	Drive Motor Control Module 2																																																													
R	2011	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																													
R	2011	Volt	Chassis	Electronic Brake Control Module		V	V																																																										
R	2011	Volt	Chassis	Parking Brake Control Module																																																													
R	2011	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																													
R	2011	Volt	Chassis	Power Steering Control Module																																																													
R	2011	Volt	Chassis	Steering Wheel Angle Sensor Module																																																													
R	2011	Volt	Body	Body Control Module																																																													
R	2011	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
R	2011	Volt	Body	Passenger Presence Module																																																													
R	2011	Volt	Body	Instrument Cluster																																																													
R	2011	Volt	Body	Radio																																																													
R	2011	Volt	Body	Digital Radio Receiver Control Module																																																													
R	2011	Volt	Body	Mobile Telephone Control Module																																																													
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 9																																																													
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 10																																																													
R	2011	Volt	Body	Remote Heater and Air Conditioning Control Module																																																													
R	2011	Volt	Body	Electric A/C Compressor Control Module																																																													
R	2011	Volt	Body	Coolant Heater Control Module																																																													
R	2011	Volt	Body	Keyless Entry Control Module																																																													
R	2011	Volt	Body	Parking Assist Control Module																																																													
R	2011	Volt	Body	Steering Column Lock Control Module																																																													
R	2011	Volt	Body	Battery Charger Control Module																																																													
R	2011	Volt	Body	Battery Energy Control Module				V	V	V	V																																																						
R	2012	Volt	Powertrain	Engine Control Module																																																													
R	2012	Volt	Powertrain	Trasmission Control Module																																																													
R	2012	Volt	Powertrain	Fuel Pump Control Module																																																													
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module																																																													
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module 2	V																																																												
R	2012	Volt	Powertrain	Drive Motor Control Module 1																																																													
R	2012	Volt	Powertrain	Drive Motor Control Module 2																																																													
R	2012	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																													
R	2012	Volt	Chassis	Electronic Brake Control Module		V	V																																																										
R	2012	Volt	Chassis	Parking Brake Control Module																																																													
R	2012	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																													
R	2012	Volt	Chassis	Power Steering Control Module																																																													
R	2012	Volt	Chassis	Steering Wheel Angle Sensor Module																																																													
R	2012	Volt	Body	Body Control Module																																																													
R	2012	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
R	2012	Volt	Body	Passenger Presence Module																																																													
R	2012	Volt	Body	Instrument Cluster																																																													
R	2012	Volt	Body	Radio																																																												
R	2012	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2012	Volt	Body	Mobile Telephone Control Module																																																												
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 9																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 10																																																															
R	2012	Volt	Body	Remote Heater and Air Conditioning Control Module																																																															
R	2012	Volt	Body	Electric A/C Compressor Control Module																																																															
R	2012	Volt	Body	Coolant Heater Control Module																																																															
R	2012	Volt	Body	Keyless Entry Control Module																																																															
R	2012	Volt	Body	Parking Assist Control Module																																																															
R	2012	Volt	Body	Steering Column Lock Control Module																																																															
R	2012	Volt	Body	Battery Charger Control Module																																																															
R	2012	Volt	Body	Battery Energy Control Module				V	V	V	V																																																							
R	2013	Volt	Powertrain	Engine Control Module																																																															
R	2013	Volt	Powertrain	Trasmission Control Module																																																															
R	2013	Volt	Powertrain	Fuel Pump Control Module																																																															
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module																																																															
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module 2	V																																																														
R	2013	Volt	Powertrain	Drive Motor Control Module 1																																																															
R	2013	Volt	Powertrain	Drive Motor Control Module 2																																																															
R	2013	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																															
R	2013	Volt	Chassis	Electronic Brake Control Module		V	V																																																												
R	2013	Volt	Chassis	Parking Brake Control Module																																																															
R	2013	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																															
R	2013	Volt	Chassis	Power Steering Control Module																																																															
R	2013	Volt	Chassis	Steering Wheel Angle Sensor Module																																																															
R	2013	Volt	Body	Body Control Module																																																															
R	2013	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
R	2013	Volt	Body	Passenger Presence Module																																																															
R	2013	Volt	Body	Instrument Cluster																																																															
R	2013	Volt	Body	Radio																																																															
R	2013	Volt	Body	Digital Radio Receiver Control Module																																																															
R	2013	Volt	Body	Multimedia Player Interface Module																																																															
R	2013	Volt	Body	Mobile Telephone Control Module																																																															
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 9																																																															
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 10																																																															
R	2013	Volt	Body	HVAC Control Module																																																															
R	2013	Volt	Body	Electric A/C Compressor Control Module																																																															
R	2013	Volt	Body	Coolant Heater Control Module																																																															
R	2013	Volt	Body	Front Seat Heating Control Module																																																															
R	2013	Volt	Body	Keyless Entry Control Module																																																															
R	2013	Volt	Body	Parking Assist Control Module																																																															
R	2013	Volt	Body	Frontview Camera Module																																																															
R	2013	Volt	Body	Steering Column Lock Control Module																																																															
R	2013	Volt	Body	Battery Charger Control Module																																																															
R	2013	Volt	Body	Battery Energy Control Module				V	V	V	V																																																							
R	2014	Volt	Powertrain	Engine Control Module																																																															
R	2014	Volt	Powertrain	Trasmission Control Module																																																															
R	2014	Volt	Powertrain	Chassis Control Module																																																															
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module																																																															
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module 2	V																																																														
R	2014	Volt	Powertrain	Drive Motor Control Module 1																																																															
R	2014	Volt	Powertrain	Drive Motor Control Module 2																																																															
R	2014	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																															
R	2014	Volt	Chassis	Electronic Brake Control Module		V	V																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2014	Volt	Chassis	Parking Brake Control Module																																																														
R	2014	Volt	Chassis	Power Steering Control Module																																																														
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module																																																														
R	2014	Volt	Body	Body Control Module																																																														
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
R	2014	Volt	Body	Passenger Presence Module																																																														
R	2014	Volt	Body	Instrument Cluster																																																														
R	2014	Volt	Body	Radio																																																														
R	2014	Volt	Body	Digital Radio Receiver Control Module																																																														
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9																																																														
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10																																																														
R	2014	Volt	Body	HVAC Control Module																																																														
R	2014	Volt	Body	Electric A/C Compressor Control Module																																																														
R	2014	Volt	Body	Coolant Heater Control Module																																																														
R	2014	Volt	Body	Front Seat Heating Control Module																																																														
R	2014	Volt	Body	Keyless Entry Control Module																																																														
R	2014	Volt	Body	Parking Assist Control Module																																																														
R	2014	Volt	Body	Frontview Camera Module																																																														
R	2014	Volt	Body	Steering Column Lock Control Module																																																														
R	2014	Volt	Body	Battery Charger Control Module																																																														
R	2014	Volt	Body	Battery Energy Control Module				V	V	V	V																																																						
R	2015	Volt	Powertrain	Engine Control Module																																																															
R	2015	Volt	Powertrain	Trasmission Control Module																																																														
R	2015	Volt	Powertrain	Chassis Control Module																																																														
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module																																																														
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2	V																																																													
R	2015	Volt	Powertrain	Drive Motor Control Module 1																																																														
R	2015	Volt	Powertrain	Drive Motor Control Module 2																																																														
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																														
R	2015	Volt	Chassis	Electronic Brake Control Module		V	V																																																											
R	2015	Volt	Chassis	Parking Brake Control Module																																																														
R	2015	Volt	Chassis	Power Steering Control Module																																																														
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module																																																														
R	2015	Volt	Body	Body Control Module																																																														
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
R	2015	Volt	Body	Passenger Presence Module																																																														
R	2015	Volt	Body	Instrument Cluster																																																														
R	2015	Volt	Body	Radio																																																														
R	2015	Volt	Body	Digital Radio Receiver Control Module																																																														
R	2015	Volt	Body	Telematics Communication Interface Control Module																																																														
R	2015	Volt	Body	HVAC Control Module																																																														
R	2015	Volt	Body	Electric A/C Compressor Control Module																																																														
R	2015	Volt	Body	Coolant Heater Control Module																																																														
R	2015	Volt	Body	Front Seat Heating Control Module																																																														
R	2015	Volt	Body	Keyless Entry Control Module																																																														
R	2015	Volt	Body	Parking Assist Control Module																																																														
R	2015	Volt	Body	Frontview Camera Module																																																														
R	2015	Volt	Body	Steering Column Lock Control Module																																																														
R	2015	Volt	Body	Battery Charger Control Module																																																														
R	2015	Volt	Body	Battery Energy Control Module				V	V	V	V																																																						
R	2016	Volt	Powertrain	Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module																																																															
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module 2	V							V																																																						
R	2016	Volt	Powertrain	Drive Motor Control Module 1																																																															
R	2016	Volt	Powertrain	Drive Motor Control Module 2																																																															
R	2016	Volt	Chassis	Electronic Brake Control Module																																																															
R	2016	Volt	Chassis	Brake Booster Control Module																																																															
R	2016	Volt	Chassis	Power Steering Control Module																																																															
R	2016	Volt	Body	Body Control Module																																																															
R	2016	Volt	Body	Pedestrian Alert Sound Control Module																																																															
R	2016	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
R	2016	Volt	Body	Passenger Presence Module																																																															
R	2016	Volt	Body	Instrument Cluster																																																															
R	2016	Volt	Body	Radio Controls																																																															
R	2016	Volt	Body	HVAC Controls																																																															
R	2016	Volt	Body	Radio																																																															
R	2016	Volt	Body	Amplifier																																																															
R	2016	Volt	Body	Human Machine Interface Control Module																																																															
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 9.7																																																															
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 10																																																															
R	2016	Volt	Body	HVAC Control Module																																																															
R	2016	Volt	Body	Electric A/C Compressor Control Module																																																															
R	2016	Volt	Body	Keyless Entry Control Module																																																															
R	2016	Volt	Body	Right Side Object Detection Control Module																																																															
R	2016	Volt	Body	Left Side Object Detection Control Module																																																															
R	2016	Volt	Body	Parking Assist Control Module																																																															
R	2016	Volt	Body	Frontview Camera Module																																																															
R	2016	Volt	Body	Steering Column Lock Control Module																																																															
R	2016	Volt	Body	Battery Energy Control Module				V	V	V	V																																																							
R	2016	Volt	Body	Long Range Radar Sensor Module																																																															
S	2004	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																															
S	2004	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																															
S	2004	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
S	2004	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																															
S	2004	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																															
S	2004	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																															
S	2004	Aveo	Powertrain	Transmission Control Module																																																															
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																															
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																															
S	2004	Aveo	Body	Supplemental Inflatable Restraint																																																															
S	2004	Aveo	Body	Remote Function Actuation																																																															
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																															
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																															
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																															
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																															
S	2005	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																															
S	2005	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
S	2005	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																															
S	2005	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																															
S	2005	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																															
S	2005	Aveo	Powertrain	Transmission Control Module																																																															
S	2005	Aveo	Chassis	Electronic Brake Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2005	Aveo	Body	Supplemental Inflatable Restraint																																																												
S	2005	Aveo	Body	Remote Function Actuation																																																													
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																													
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																													
S	2006	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																													
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																													
S	2006	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																													
S	2006	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																													
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																													
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																													
S	2006	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																													
S	2006	Aveo	Chassis	Electronic Brake Control Module																																																														
S	2006	Aveo	Body	Supplemental Inflatable Restraint																																																													
S	2006	Aveo	Body	Remote Function Actuation																																																													
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																													
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																													
S	2007	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																													
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																													
S	2007	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																													
S	2007	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																													
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																													
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																													
S	2007	Aveo	Powertrain	Transmission Control Module 4 Speed																																																													
S	2007	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																													
S	2007	Aveo	Chassis	Electronic Brake Control Module																																																													
S	2007	Aveo	Body	Supplemental Inflatable Restraint																																																													
S	2007	Aveo	Body	Remote Function Actuation																																																													
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																													
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																													
S	2008	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																													
S	2008	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																													
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																													
S	2008	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																													
S	2008	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																													
S	2008	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																													
S	2008	Aveo	Powertrain	Transmission Control Module																																																													
S	2008	Aveo	Powertrain	Transmission Control Module																																																													
S	2008	Aveo	Chassis	Electronic Brake Control Module																																																													
S	2008	Aveo	Chassis	Tire Pressure Monitor																																																													
S	2008	Aveo	Body	Supplemental Inflatable Restraint																																																												
S	2008	Aveo	Body	Remote Function Actuation																																																												
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																												
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																												
S	2009	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																												
S	2009	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																												
S	2009	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2009	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																												
S	2009	Aveo	Powertrain	Transmission Control Module																																																													
S	2009	Aveo	Powertrain	Transmission Control Module																																																												
S	2009	Aveo	Powertrain	Other Auto Transmission System																																																												
S	2009	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2009	Aveo	Chassis	Tire Pressure Monitor																																																												
S	2009	Aveo	Body	Supplemental Inflatable Restraint																																																												
S	2009	Aveo	Body	Remote Function Actuation																																																												
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																												
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																												
S	2010	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
S	2010	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
S	2010	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																												
S	2010	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
S	2010	Aveo	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																												
S	2010	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																												
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2010	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2010	Aveo	Chassis	Tire Pressure Monitor																																																												
S	2010	Aveo	Body	Supplemental Inflatable Restraint																																																												
S	2010	Aveo	Body	Remote Function Actuation																																																												
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																												
S	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																												
S	2010	Sail	Powertrain	Transmission Control Module																																																												
S	2010	Sail	Chassis	Electronic Brake Control Module																																																												
S	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																												
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																												
S	2011	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
S	2011	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
S	2011	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																												
S	2011	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
S	2011	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																												
S	2011	Aveo	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																												
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2011	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2011	Aveo	Chassis	Tire Pressure Monitor																																																												
S	2011	Aveo	Body	Supplemental Inflatable Restraint																																																												
S	2011	Aveo	Body	Remote Function Actuation																																																												
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																												
S	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																												
S	2011	Sail	Powertrain	Transmission Control Module																																																												
S	2011	Sail	Chassis	Electronic Brake Control Module																																																												
S	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
S	2012	Aveo	Powertrain	Fuel Pump Control Module																																																										
S	2012	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	Aveo	Chassis	Electric Power Steering Control Module																																																										
S	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2012	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2012	Aveo	Body	Body Control Module Hatchback																																																										
S	2012	Aveo	Body	Body Control Module Sedan																																																										
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	Aveo	Body	Passenger Presence Module																																																										
S	2012	Aveo	Body	Instrument Cluster																																																										
S	2012	Aveo	Body	Radio																																																										
S	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
S	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2012	Aveo	Body	Front Seat Heating Control Module																																																										
S	2012	Aveo	Body	Remote Function Actuation																																																										
S	2012	Aveo	Body	Parking Assist Control Module																																																										
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																													
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																														
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																														
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																														
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																														
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																														
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																														
S	2012	Sail	Powertrain	Transmission Control Module																																																														
S	2012	Sail	Chassis	Electronic Brake Control Module																																																														
S	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																														
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																														
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																														
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																														
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																														
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																														
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																														
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																														
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																														
S	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																														
S	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																														
S	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																														
S	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																														
S	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																														
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																														
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																														
S	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																														
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																											V																		
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																											V																		
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																														
S	2013	Aveo	Powertrain	Fuel Injector Control Module																																																														
S	2013	Aveo	Powertrain	Fuel Pump Control Module																																																														
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																														
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																														
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																														
S	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2013	Aveo	Chassis	Electric Power Steering Control Module																																																														
S	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2013	Aveo	Body	Body Control Module Hatchback																																																														
S	2013	Aveo	Body	Body Control Module Sedan																																																														
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2013	Aveo	Body	Passenger Presence Module																																																														
S	2013	Aveo	Body	Instrument Cluster																																																														
S	2013	Aveo	Body	Radio																																																														
S	2013	Aveo	Body	Telematics Communication Interface Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
S	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
S	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
S	2013	Aveo	Body	Front Seat Heating Control Module																																																												
S	2013	Aveo	Body	Remote Function Actuation																																																												
S	2013	Aveo	Body	Parking Assist Control Module																																																												
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																												
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																												
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																												
S	2013	Sail	Powertrain	Transmission Control Module																																																												
S	2013	Sail	Chassis	Electronic Brake Control Module																																																												
S	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																												
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																												
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
S	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
S	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																												
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																												
S	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																												
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																											V																
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																											V																
S	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																												
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
S	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
S	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
S	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
S	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
S	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
S	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
S	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
S	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																											V																
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																											V																
S	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																											V													
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																											V													
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
S	2014	Aveo	Powertrain	Chassis Control Module																																																								
S	2014	Aveo	Powertrain	Fuel Injector Control Module																																																								
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2014	Aveo	Chassis	Power Steering Control Module																																																								
S	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2014	Aveo	Body	Body Control Module Hatchback																																																								
S	2014	Aveo	Body	Body Control Module Sedan																																																								
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2014	Aveo	Body	Instrument Cluster																																																								
S	2014	Aveo	Body	Radio																																																								
S	2014	Aveo	Body	Telematics Communication Interface Control Module																																																								
S	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
S	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
S	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								
S	2014	Aveo	Body	Front Seat Heating Control Module																																																								
S	2014	Aveo	Body	Keyless Entry Control Module																																																								
S	2014	Aveo	Body	Parking Assist Control Module																																																								
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
S	2014	Sail	Powertrain	Transmission Control Module																																																								
S	2014	Sail	Chassis	Electronic Brake Control Module																																																								
S	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																								
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																								
S	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																								
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																								
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																								
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																								
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
S	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																													
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
S	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
S	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																													
S	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																													
S	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																													
S	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																													
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																													
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																													
S	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																													
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																												V																
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																												V																
S	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																													
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																												V																
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																												V																
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																													
S	2015	Aveo	Powertrain	Chassis Control Module																																																														
S	2015	Aveo	Powertrain	Fuel Injector Control Module																																																														
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																														
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																														
S	2015	Aveo	Chassis	Power Steering Control Module																																																														
S	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2015	Aveo	Body	Body Control Module Hatchback																																																														
S	2015	Aveo	Body	Body Control Module Sedan																																																														
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2015	Aveo	Body	Instrument Cluster																																																														
S	2015	Aveo	Body	Radio																																																													
S	2015	Aveo	Body	Telematics Communication Interface Control Module																																																														
S	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																														
S	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
S	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																														
S	2015	Aveo	Body	Front Seat Heating Control Module																																																														
S	2015	Aveo	Body	Keyless Entry Control Module																																																														
S	2015	Aveo	Body	Parking Assist Control Module																																																														
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																														
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																														
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																														
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																														
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																														
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																														
S	2015	Sail	Powertrain	Transmission Control Module																																																														
S	2015	Sail	Chassis	Electronic Brake Control Module																																																														
S	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																														
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																														
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
S	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
S	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
S	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																												V																
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																												V																
S	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																												V																
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																												V																
S	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
S	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
S	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
S	2016	Aveo	Powertrain	Chassis Control Module																																																												
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2016	Aveo	Chassis	Power Steering Control Module																																																												
S	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2016	Aveo	Body	Body Control Module Hatchback																																																												
S	2016	Aveo	Body	Body Control Module Sedan																																																												
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2016	Aveo	Body	Instrument Cluster																																																												
S	2016	Aveo	Body	Radio																																																											
S	2016	Aveo	Body	Telematics Communication Interface Control Module																																																												
S	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
S	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
S	2016	Aveo	Body	Front Seat Heating Control Module																																																											
S	2016	Aveo	Body	Parking Assist Control Module																																																											
S	2016	Aveo	Body	Keyless Entry Control Module																																																											
S	2016	Aveo	Body	Frontview Camera Module																																																											
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																												
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																													
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																													
S	2016	Sail	Powertrain	Transmission Control Module																																																													
S	2016	Sail	Chassis	Electronic Brake Control Module																																																													
S	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2004	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																													
T	2004	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
T	2004	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																													
T	2004	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																													
T	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																													
T	2004	ALL	Powertrain	Transmission Control Module																																																													
T	2004	ALL	Chassis	Electronic Brake Control Module																																																													
T	2004	ALL	Chassis	Electronic Brake Control Module																																																													
T	2004	ALL	Body	Supplemental Inflatable Restraint																																																													
T	2004	ALL	Body	Remote Function Actuation																																																													
T	2005	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																													
T	2005	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
T	2005	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																													
T	2005	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																													
T	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																													
T	2005	ALL	Powertrain	Transmission Control Module																																																													
T	2005	ALL	Chassis	Electronic Brake Control Module																																																													
T	2005	ALL	Body	Supplemental Inflatable Restraint																																																													
T	2005	ALL	Body	Remote Function Actuation																																																													
T	2006	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																													
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																													
T	2006	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																													
T	2006	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																													
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																													
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																													
T	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																													
T	2006	ALL	Chassis	Electronic Brake Control Module																																																													
T	2006	ALL	Body	Supplemental Inflatable Restraint																																																													
T	2006	ALL	Body	Remote Function Actuation																																																													
T	2007	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																													
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																													
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																													
T	2007	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																													
T	2007	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																													
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																													
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																													
T	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																													
T	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																													
T	2007	ALL	Chassis	Electronic Brake Control Module																																																													
T	2007	ALL	Body	Supplemental Inflatable Restraint																																																													
T	2007	ALL	Body	Remote Function Actuation																																																													
T	2008	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																													
T	2008	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																													
T	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2008	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																														
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																															
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																															
T	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																															
T	2008	ALL	Powertrain	Transmission Control Module																																																															
T	2008	ALL	Powertrain	Transmission Control Module																																																															
T	2008	ALL	Chassis	Electronic Brake Control Module																																																															
T	2008	ALL	Chassis	Tire Pressure Monitor																																																															
T	2008	ALL	Body	Supplemental Inflatable Restraint																																																															
T	2008	ALL	Body	Remote Function Actuation																																																															
T	2008	ALL	Body	Passenger Presence System																																																															
T	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																															
T	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																															
T	2009	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																															
T	2009	ALL	Powertrain	Transmission Control Module																																																															
T	2009	ALL	Powertrain	Transmission Control Module																																																															
T	2009	ALL	Chassis	Electronic Brake Control Module																																																															
T	2009	ALL	Chassis	Tire Pressure Monitor																																																															
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
T	2009	ALL	Body	Instrument Panel Cluster																																																															
T	2009	ALL	Body	Passenger Presence System																																																															
T	2009	ALL	Body	Theft Deterrent Module																																																															
T	2009	ALL	Body	Radio																																																															
T	2009	ALL	Body	Remote Function Actuation																																																															
T	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																															
T	2010	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																															
T	2010	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																															
T	2010	ALL	Powertrain	Transmission Control Module																																																															
T	2010	ALL	Powertrain	Transmission Control Module																																																															
T	2010	ALL	Chassis	Electronic Brake Control Module																																																															
T	2010	ALL	Chassis	Tire Pressure Monitor																																																															
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
T	2010	ALL	Body	Instrument Panel Cluster																																																															
T	2010	ALL	Body	Passenger Presence System																																																															
T	2010	ALL	Body	Theft Deterrent Module																																																															
T	2010	ALL	Body	Radio																																																															
T	2010	ALL	Body	Remote Function Actuation																																																															
T	2011	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																															
T	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																															
T	2011	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																															
T	2011	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																															
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																															
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module Argentia																																																															
T	2011	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																															
T	2011	ALL	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																															
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																															
T	2011	ALL	Chassis	Electronic Brake Control Module																																																															
T	2011	ALL	Chassis	Tire Pressure Monitor																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2011	ALL	Body	Instrument Panel Cluster																																																												
T	2011	ALL	Body	Passenger Presence System																																																												
T	2011	ALL	Body	Theft Deterrent Module																																																												
T	2011	ALL	Body	Radio																																																												
T	2011	ALL	Body	Remote Function Actuation																																																												
T	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																												
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																												
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																												
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																												
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
T	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
T	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																												
T	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
T	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																												
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																												
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
T	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
T	2012	Aveo	Powertrain	Fuel Injector Control Module																																																												
T	2012	Aveo	Powertrain	Fuel Pump Control Module																																																												
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2012	Aveo	Chassis	Electric Power Steering Control Module																																																												
T	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2012	Aveo	Chassis	Tire Pressure Monitor																																																												
T	2012	Aveo	Body	Body Control Module Hatchback																																																												
T	2012	Aveo	Body	Body Control Module Sedan																																																												
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2012	Aveo	Body	Passenger Presence Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2012	Aveo	Body	Instrument Cluster																																																											
T	2012	Aveo	Body	Radio																																																											
T	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																												V	V												
T	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
T	2012	Aveo	Body	Front Seat Heating Control Module																																																											
T	2012	Aveo	Body	Remote Function Actuation																																																											
T	2012	Aveo	Body	Parking Assist Control Module																																																											
T	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																											
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
T	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
T	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																											
T	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
T	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																											V																
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																											V																
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
T	2013	Aveo	Powertrain	Fuel Injector Control Module																																																											
T	2013	Aveo	Powertrain	Fuel Pump Control Module																																																											
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2013	Aveo	Chassis	Electric Power Steering Control Module																																																											
T	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2013	Aveo	Body	Body Control Module Hatchback																																																											
T	2013	Aveo	Body	Body Control Module Sedan																																																											
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	Aveo	Body	Passenger Presence Module																																																											
T	2013	Aveo	Body	Instrument Cluster																																																											
T	2013	Aveo	Body	Radio																																																											
T	2013	Aveo	Body	Telematics Communication Interface Control Module																																																											
T	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2013	Aveo	Body	Front Seat Heating Control Module																																																														
T	2013	Aveo	Body	Remote Function Actuation																																																														
T	2013	Aveo	Body	Parking Assist Control Module																																																														
T	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																														
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																														
T	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																														
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																														
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																													V																
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																													V																
T	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																														
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																														
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																														
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														
T	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																														
T	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																														
T	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																														
T	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																														
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																														
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																														
T	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																														
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																													V																
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																													V																
T	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																														
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																													V																
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																													V																
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																														
T	2014	Aveo	Powertrain	Chassis Control Module																																																														
T	2014	Aveo	Powertrain	Fuel Injector Control Module																																																														
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																														
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																														
T	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																														
T	2014	Aveo	Chassis	Power Steering Control Module																																																														
T	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																														
T	2014	Aveo	Body	Body Control Module Hatchback																																																														
T	2014	Aveo	Body	Body Control Module Sedan																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2014	Aveo	Body	Instrument Cluster																																																											
T	2014	Aveo	Body	Radio																																																										
T	2014	Aveo	Body	Telematics Communication Interface Control Module																																																											
T	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
T	2014	Aveo	Body	Front Seat Heating Control Module																																																											
T	2014	Aveo	Body	Keyless Entry Control Module																																																											
T	2014	Aveo	Body	Parking Assist Control Module																																																											
T	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																											
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																											
T	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																											
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																											
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																											
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
T	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																											
T	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																											
T	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																											
T	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																												V															
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																												V															
T	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																												V															
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																												V															
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
T	2015	Aveo	Powertrain	Chassis Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2015	Aveo	Powertrain	Fuel Injector Control Module																																																												
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2015	Aveo	Chassis	Power Steering Control Module																																																												
T	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2015	Aveo	Body	Body Control Module Hatchback																																																												
T	2015	Aveo	Body	Body Control Module Sedan																																																												
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2015	Aveo	Body	Instrument Cluster																																																												
T	2015	Aveo	Body	Radio																																																												
T	2015	Aveo	Body	Telematics Communication Interface Control Module																																																												
T	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
T	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
T	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
T	2015	Aveo	Body	Front Seat Heating Control Module																																																												
T	2015	Aveo	Body	Keyless Entry Control Module																																																												
T	2015	Aveo	Body	Parking Assist Control Module																																																												
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
T	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
T	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																														V														
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																															V													
T	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																															V													
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																															V													
T	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
T	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
T	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
T	2016	Aveo	Powertrain	Chassis Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2016	Aveo	Chassis	Power Steering Control Module																																																												
T	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2016	Aveo	Body	Body Control Module Hatchback																																																												
T	2016	Aveo	Body	Body Control Module Sedan																																																												
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	Aveo	Body	Instrument Cluster																																																												
T	2016	Aveo	Body	Radio																																																											
T	2016	Aveo	Body	Telematics Communication Interface Control Module																																																												
T	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
T	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
T	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
T	2016	Aveo	Body	Front Seat Heating Control Module																																																												
T	2016	Aveo	Body	Parking Assist Control Module																																																												
T	2016	Aveo	Body	Keyless Entry Control Module																																																												
T	2016	Aveo	Body	Frontview Camera Module																																																												
U	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
U	2004	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																												
U	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
U	2004	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																												
U	2004	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
U	2004	ALL	Chassis	Electronic Brake Control Module																																																												
U	2004	ALL	Chassis	Electronic Brake Control Module																																																												
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
U	2004	ALL	Body	Remote Function Actuation																																																												
U	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
U	2005	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																												
U	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
U	2005	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																												
U	2005	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
U	2005	ALL	Chassis	Electronic Brake Control Module																																																												
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
U	2005	ALL	Body	Remote Function Actuation																																																												
U	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
U	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
U	2006	ALL	Powertrain	Transmission Control Module																																																												
U	2006	ALL	Chassis	Electronic Brake Control Module																																																												
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
U	2006	ALL	Body	Remote Function Actuation																																																												
U	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
U	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
U	2007	ALL	Powertrain	Transmission Control Module																																																												
U	2007	ALL	Chassis	Electronic Brake Control Module																																																												
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
U	2007	ALL	Body	Remote Function Actuation																																																															
U	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																																
U	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																																
U	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																																
U	2008	ALL	Powertrain	Transmission Control Module																																																																
U	2008	ALL	Chassis	Electronic Brake Control Module																																																																
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																																
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																																
U	2008	ALL	Body	Remote Function Actuation																																																																
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																																
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																																
U	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																																
U	2010	Sail	Powertrain	Transmission Control Module																																																																
U	2010	Sail	Chassis	Electronic Brake Control Module																																																																
U	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																																
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																																
U	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																																
U	2011	Sail	Powertrain	Transmission Control Module																																																																
U	2011	Sail	Chassis	Electronic Brake Control Module																																																																
U	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																																
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																																
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																																
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																																
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																																
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																																
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																																
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																																
U	2012	Sail	Powertrain	Transmission Control Module																																																																
U	2012	Sail	Chassis	Electronic Brake Control Module																																																																
U	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																																
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																																
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																																
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																																
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																																
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																																
U	2013	Sail	Powertrain	Transmission Control Module																																																																
U	2013	Sail	Chassis	Electronic Brake Control Module																																																																
U	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																																
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																																
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																																
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																																
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																																
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																																
U	2014	Sail	Powertrain	Transmission Control Module																																																																
U	2014	Sail	Chassis	Electronic Brake Control Module																																																																
U	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																																

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																													
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																													
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
U	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																													
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																													
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																													
U	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																													
U	2015	Sail	Powertrain	Transmission Control Module																																																													
U	2015	Sail	Chassis	Electronic Brake Control Module																																																													
U	2015	Sail	Chassis	Electronic Brake Control Module																																																													
U	2015	Sail	Chassis	Power Steering Control Module																																																													
U	2015	Sail	Body	Body Control Module																																																													
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2015	Sail	Body	Radio/HVAC Control																																																													
U	2015	Sail	Body	HVAC Control Module																																																													
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																													
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																													
U	2016	Sail	Powertrain	1.2L LMU Transmission Control Module																																																													
U	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																													
U	2016	Sail	Powertrain	1.3L LDV Transmission Control Module																																																													
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																													
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																													
U	2016	Sail	Powertrain	1.4L LCU Transmission Control Module																																																													
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																													
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																													
U	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																													
U	2016	Sail	Chassis	Electronic Brake Control Module																																																													
U	2016	Sail	Chassis	Electronic Brake Control Module																																																													
U	2016	Sail	Chassis	Power Steering Control Module																																																													
U	2016	Sail	Body	Body Control Module																																																													
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2016	Sail	Body	Radio/HVAC Control																																																													
U	2016	Sail	Body	Radio																																																												
U	2016	Sail	Body	HVAC Control Module																																																												
V	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
V	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
V	2004	ALL	Powertrain	Transmission Control Module 4 Speed																																																												
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																												
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																												
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2004	ALL	Body	ISU																																																											
V	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
V	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
V	2005	ALL	Powertrain	Transmission Control Module 4 Speed																																																												
V	2005	ALL	Chassis	Electronic Brake Control Module																																																												
V	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2005	ALL	Body	ISU																																																											
V	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
V	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
V	2006	ALL	Powertrain	Transmission Control Module 4 Speed																																																												
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																												
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																												
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2006	ALL	Body	ISU																																																											
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																												
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector Control Module																																																												
V	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
V	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																												
V	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																												
V	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
V	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																												
V	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																												
V	2007	ALL	Chassis	Electronic Brake Control Module																																																												
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2007	ALL	Body	ISU																																																											
V	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																												
V	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
V	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																												
V	2008	ALL	Chassis	Electronic Brake Control Module																																									V																		
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2008	ALL	Body	ISU																																																											
V	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																												
V	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
V	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																												
V	2009	ALL	Chassis	Electronic Brake Control Module																																									V																		
V	2009	ALL	Body	ISU																																																											
V	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																												
V	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																												
V	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
V	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																												
V	2010	ALL	Chassis	Electronic Brake Control Module																																									V																		
V	2010	ALL	Body	ISU																																																											
V	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																												
V	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																												
V	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
V	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																												
V	2011	ALL	Chassis	Electronic Brake Control Module																																									V																		
V	2011	ALL	Body	ISU																																																											
W	2004	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																												
W	2004	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																												
W	2004	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																												
W	2004	ALL	Powertrain	Transmission Control Module																																																												
W	2004	ALL	Body	Body Control Module																																																											
W	2004	ALL	Body	Digital Radio Receiver																																																											
W	2004	ALL	Body	Driver Information Center																																																											
W	2004	ALL	Body	Heating and Air Conditioning																																																											
W	2004	ALL	Body	Instrument Panel Cluster																																																											
W	2004	ALL	Body	Personalization																																																											
W	2004	ALL	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
W	2004	ALL	Body	Supplemental Inflatable Restraint																																																													
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																														
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																														
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																														
W	2005	ALL	Powertrain	Transmission Control Module																																																														
W	2005	ALL	Body	Body Control Module																																																													
W	2005	ALL	Body	Digital Radio Receiver																																																													
W	2005	ALL	Body	Driver Information Center																																																													
W	2005	ALL	Body	Heating and Air Conditioning																																																													
W	2005	ALL	Body	Instrument Panel Cluster																																																													
W	2005	ALL	Body	Personalization																																																													
W	2005	ALL	Body	Radio																																																													
W	2005	ALL	Body	Supplemental Inflatable Restraint																																																													
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																													
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																													
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																													
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																													
W	2006	ALL	Powertrain	Transmission Control Module																																																													
W	2006	ALL	Chassis	Anti-lock Brake System																																																													
W	2006	ALL	Body	Digital Radio Receiver																																																													
W	2006	ALL	Body	Radio																																																												
W	2006	ALL	Body	Instrument Panel Cluster																																																													
W	2006	ALL	Body	Seat																																																												
W	2006	ALL	Body	Theft Deterrent Module																																																													
W	2006	ALL	Body	Body Control Module																																																													
W	2006	ALL	Body	HVAC C67 Single																																																													
W	2006	ALL	Body	HVAC CJ3 Dual																																																													
W	2006	ALL	Body	Remote Control Door Lock Receiver																																																													
W	2006	ALL	Body	Supplemental Inflatable Restraint																																																													
W	2006	ALL	Body	Passenger Presence System																																																													
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																													
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																													
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																													
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module																																																													
W	2007	ALL	Powertrain	Transmission Control Module																																																													
W	2007	ALL	Chassis	Electronic Brake Control Module																																																													
W	2007	ALL	Body	Body Control Module																																																													
W	2007	ALL	Body	Digital Radio Receiver																																																													
W	2007	ALL	Body	Heated Seat Module																																																													
W	2007	ALL	Body	HVAC C67 Single																																																													
W	2007	ALL	Body	HVAC CJ3 Dual																																																													
W	2007	ALL	Body	Instrument Panel Cluster																																																													
W	2007	ALL	Body	Passenger Presence System																																																													
W	2007	ALL	Body	Radio																																																												
W	2007	ALL	Body	Supplemental Inflatable Restraint																																																													
W	2007	ALL	Body	Theft Deterrent Module																																																													
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																													
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																													
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module																																																													
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																									V																			
W	2008	ALL	Powertrain	Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
W	2008	ALL	Chassis	Electronic Brake Control Module																																																												
W	2008	ALL	Body	Body Control Module																																																												
W	2008	ALL	Body	Digital Radio Receiver																																																												
W	2008	ALL	Body	Heated Seat Module																																																												
W	2008	ALL	Body	HVAC C67 Single																																																												
W	2008	ALL	Body	HVAC CJ3 Dual																																																												
W	2008	ALL	Body	Instrument Panel Cluster																																																												
W	2008	ALL	Body	Passenger Presence System																																																												
W	2008	ALL	Body	Radio																																																												
W	2008	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2008	ALL	Body	Theft Deterrent Module																																																												
W	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																												
W	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																												
W	2009	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																												
W	2009	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																									V																			
W	2009	ALL	Powertrain	Transmission Control Module																																																												
W	2009	ALL	Chassis	Electronic Brake Control Module																																																													
W	2009	ALL	Body	Body Control Module																																																												
W	2009	ALL	Body	Digital Radio Receiver																																																												
W	2009	ALL	Body	Heated Seat Module																																																												
W	2009	ALL	Body	HVAC C67 Single																																																												
W	2009	ALL	Body	HVAC CJ3 Dual																																																												
W	2009	ALL	Body	Instrument Panel Cluster																																																												
W	2009	ALL	Body	Passenger Presence System																																																												
W	2009	ALL	Body	Radio																																																												
W	2009	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2009	ALL	Body	Theft Deterrent Module																																																												
W	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																												
W	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																												
W	2010	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																												
W	2010	ALL	Powertrain	Transmission Control Module																																																												
W	2010	ALL	Chassis	Electronic Brake Control Module																																																												
W	2010	ALL	Body	Body Control Module																																																												
W	2010	ALL	Body	Digital Radio Receiver																																																												
W	2010	ALL	Body	Heated Seat Module																																																												
W	2010	ALL	Body	HVAC C67 Single																																																												
W	2010	ALL	Body	HVAC CJ3 Dual																																																												
W	2010	ALL	Body	Instrument Panel Cluster																																																												
W	2010	ALL	Body	Passenger Presence System																																																												
W	2010	ALL	Body	Radio																																																												
W	2010	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2010	ALL	Body	Theft Deterrent Module																																																												
W	2011	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																												
W	2011	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																												
W	2011	ALL	Powertrain	Transmission Control Module																																																												
W	2011	ALL	Chassis	Electronic Brake Control Module																																																												
W	2011	ALL	Body	Body Control Module																																																												
W	2011	ALL	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
W	2011	ALL	Body	Heated Seat Module																																																											
W	2011	ALL	Body	HVAC C67 Single																																																												
W	2011	ALL	Body	HVAC CJ3 Dual																																																												
W	2011	ALL	Body	Instrument Panel Cluster																																																												
W	2011	ALL	Body	Passenger Presence System																																																												
W	2011	ALL	Body	Radio																																																												
W	2011	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2011	ALL	Body	Theft Deterrent Module																																																												
W	2012	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																												
W	2012	ALL	Powertrain	Transmission Control Module																																																												
W	2012	ALL	Powertrain	Fuel Pump Control Module																																																												
W	2012	ALL	Chassis	Electronic Brake Control Module																																																												
W	2012	ALL	Body	Body Control Module																																																												
W	2012	ALL	Body	Digital Radio Receiver																																																												
W	2012	ALL	Body	Heated Seat Module																																																												
W	2012	ALL	Body	HVAC C67 Single																																																												
W	2012	ALL	Body	HVAC CJ3 Dual																																																												
W	2012	ALL	Body	Instrument Panel Cluster																																																												
W	2012	ALL	Body	Passenger Presence System																																																												
W	2012	ALL	Body	Radio																																																												
W	2012	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2012	ALL	Body	Theft Deterrent Module																																																												
W	2013	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																												
W	2013	ALL	Powertrain	Transmission Control Module																																																												
W	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
W	2013	ALL	Chassis	Electronic Brake Control Module																																																												
W	2013	ALL	Body	Body Control Module																																																												
W	2013	ALL	Body	Digital Radio Receiver																																																												
W	2013	ALL	Body	Heated Seat Module																																																												
W	2013	ALL	Body	HVAC C67 Single																																																												
W	2013	ALL	Body	HVAC CJ3 Dual																																																												
W	2013	ALL	Body	Instrument Panel Cluster																																																												
W	2013	ALL	Body	Passenger Presence System																																																												
W	2013	ALL	Body	Radio																																																												
W	2013	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2013	ALL	Body	Theft Deterrent Module																																																												
W	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
W	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
W	2014	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																												
W	2014	Impala	Chassis	Electronic Brake Control Module																																																												
W	2014	Impala	Body	Body Control Module																																																												
W	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
W	2014	Impala	Body	Passenger Presence Module																																																												
W	2014	Impala	Body	Instrument Cluster																																																												
W	2014	Impala	Body	Radio																																																												
W	2014	Impala	Body	Digital Radio Receiver Control Module																																																												
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																												
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
W	2014	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
W	2014	Impala	Body	HVAC Manual Control Single Zone (C67)																																																														
W	2014	Impala	Body	Front Seat Heating Control Module																																																														
W	2014	Impala	Body	Remote Control Door Lock Receiver																																																														
W	2014	Impala	Body	Theft Deterrent Module																																																														
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																														
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																														
W	2014	Lumina	Powertrain	(2) 6.0L L77 Transmission Control Module																																																														
W	2014	Lumina	Powertrain	Fuel Injector Control Module																																																														
W	2014	Lumina	Powertrain	Chassis Control Module																																																														
W	2014	Lumina	Chassis	Electronic Brake Control Module																																																														
W	2014	Lumina	Chassis	Parking Brake Control Module																																																														
W	2014	Lumina	Chassis	Power Steering Control Module																																																														
W	2014	Lumina	Chassis	Steering Wheel Angle Sensor Module																																																														
W	2014	Lumina	Chassis	Suspension Control Module																																																														
W	2014	Lumina	Body	Body Control Module Coupe																																																														
W	2014	Lumina	Body	Body Control Module Sedan																																																														
W	2014	Lumina	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
W	2014	Lumina	Body	Instrument Cluster																																																														
W	2014	Lumina	Body	Head-Up Display Module																																																														
W	2014	Lumina	Body	Radio Control																																																														
W	2014	Lumina	Body	HVAC Control																																																														
W	2014	Lumina	Body	Headlamp Control Module																																																														
W	2014	Lumina	Body	Trailer Interface Control Module																																																														
W	2014	Lumina	Body	Radio																																																														
W	2014	Lumina	Body	HVAC Control Module																																																														
W	2014	Lumina	Body	Keyless Entry Control Module																																																														
W	2014	Lumina	Body	Right Side Object Detection Control Module																																																														
W	2014	Lumina	Body	Left Side Object Detection Control Module																																																														
W	2014	Lumina	Body	Parking Assist Control Module																																																														
W	2014	Lumina	Body	Frontview Camera Module																																																														
W	2014	Lumina	Body	Steering Column Lock Control Module																																																														
W	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
W	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
W	2015	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																														
W	2015	Impala	Chassis	Electronic Brake Control Module																																																														
W	2015	Impala	Body	Body Control Module																																																														
W	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
W	2015	Impala	Body	Passenger Presence Module																																																														
W	2015	Impala	Body	Instrument Cluster																																																														
W	2015	Impala	Body	Radio																																																														
W	2015	Impala	Body	Digital Radio Receiver Control Module																																																														
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 9																																																														
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 10																																																														
W	2015	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
W	2015	Impala	Body	HVAC Manual Control Single Zone (C67)																																																														
W	2015	Impala	Body	Front Seat Heating Control Module																																																														
W	2015	Impala	Body	Remote Control Door Lock Receiver																																																														
W	2015	Impala	Body	Theft Deterrent Module																																																														
W	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
W	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
W	2016	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																											
W	2016	Impala	Chassis	Electronic Brake Control Module																																																												
W	2016	Impala	Body	Body Control Module																																																											
W	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
W	2016	Impala	Body	Passenger Presence Module																																																											
W	2016	Impala	Body	Instrument Cluster																																																											
W	2016	Impala	Body	Radio																																																											
W	2016	Impala	Body	Digital Radio Receiver Control Module																																																											
W	2016	Impala	Body	Telematics Communication Interface Control Module																																																											
W	2016	Impala	Body	HVAC Manual Control Dual Zone (CJ2)																																																											
W	2016	Impala	Body	HVAC Manual Control Single Zone (C67)																																																											
W	2016	Impala	Body	Front Seat Heating Control Module																																																											
W	2016	Impala	Body	Remote Control Door Lock Receiver																																																											
W	2016	Impala	Body	Theft Deterrent Module																																																											
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Auto																																																											
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Manual																																																											
Y	2004	ALL	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																											
Y	2004	ALL	Powertrain	Transmission Control Module																																																											
Y	2004	ALL	Chassis	RTD										V																																																
Y	2004	ALL	Body	Body Control Module																																																										
Y	2004	ALL	Body	Heating and Air Conditioning																																																										
Y	2004	ALL	Body	Instrument Panel Cluster																																																										
Y	2004	ALL	Body	Left Door Control Module																																																										
Y	2004	ALL	Body	Radio																																																										
Y	2004	ALL	Body	Remote Function Actuation																																																										
Y	2004	ALL	Body	Right Door Control Module																																																										
Y	2004	ALL	Body	Seat Control Module																																																										
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2005	ALL	Powertrain	Engine Control Module																																																										
Y	2005	ALL	Powertrain	Transmission Control Module																																																										
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2005	ALL	Chassis	Electronic Suspension Control																																																										
Y	2005	ALL	Chassis	Steering Wheel and Column																																																										
Y	2005	ALL	Body	Amplifier																																																									
Y	2005	ALL	Body	Body Control Module											V																															V															
Y	2005	ALL	Body	Digital Radio Receiver																																																										
Y	2005	ALL	Body	Driver Door Module																																																										
Y	2005	ALL	Body	Driver Door Switch																																																										
Y	2005	ALL	Body	Driver Position Module																																																										
Y	2005	ALL	Body	Folding Top Module																		V																																								
Y	2005	ALL	Body	Head Up Display																																																										
Y	2005	ALL	Body	HVAC Control Module																					V																																					
Y	2005	ALL	Body	Instrument Panel Cluster																																																										
Y	2005	ALL	Body	Navigation Radio																																																										
Y	2005	ALL	Body	Passenger Door Module																																																										
Y	2005	ALL	Body	Radio																																																										
Y	2005	ALL	Body	Remote Control Door Lock Receiver																								V	V																																	
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2006	ALL	Powertrain	Engine Control Module																																																										
Y	2006	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2006	ALL	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Y	2006	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2006	ALL	Chassis	Electronic Suspension Control																																																												
Y	2006	ALL	Chassis	Steering Wheel and Column																																																												
Y	2006	ALL	Body	Body Control Module											V																																V															
Y	2006	ALL	Body	CD Changer																																																											
Y	2006	ALL	Body	Digital Radio Receiver																																																												
Y	2006	ALL	Body	Driver Door Module																																																												
Y	2006	ALL	Body	Driver Door Switch																																																												
Y	2006	ALL	Body	Driver Position Module																																																												
Y	2006	ALL	Body	Folding Top Module																		V																																										
Y	2006	ALL	Body	Head Up Display																																																												
Y	2006	ALL	Body	HVAC Control Module																					V																																								
Y	2006	ALL	Body	Instrument Panel Cluster																																																												
Y	2006	ALL	Body	Navigation Radio																																																												
Y	2006	ALL	Body	Passenger Door Module																																																												
Y	2006	ALL	Body	Radio																																																												
Y	2006	ALL	Body	Remote Control Door Lock Receiver																								V	V																																				
Y	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2007	ALL	Powertrain	Engine Control Module																																																													
Y	2007	ALL	Powertrain	Exhaust Flow Control Module																																																													
Y	2007	ALL	Powertrain	Transmission Control Module																																																													
Y	2007	ALL	Chassis	Electronic Brake Control Module																																																													
Y	2007	ALL	Chassis	Electronic Suspension Control																																																													
Y	2007	ALL	Body	Body Control Module											V																																V															
Y	2007	ALL	Body	CD Changer																																																												
Y	2007	ALL	Body	Digital Radio Receiver																																																													
Y	2007	ALL	Body	Driver Door Module																																																												
Y	2007	ALL	Body	Driver Door Switch																																																												
Y	2007	ALL	Body	Driver Position Module																																																												
Y	2007	ALL	Body	Folding Top Module																		V																																										
Y	2007	ALL	Body	Head Up Display																																																												
Y	2007	ALL	Body	HVAC Control Module																					V																																								
Y	2007	ALL	Body	Instrument Panel Cluster																																																												
Y	2007	ALL	Body	Navigation Radio																																																												
Y	2007	ALL	Body	Passenger Door Module																																																												
Y	2007	ALL	Body	Radio																																																												
Y	2007	ALL	Body	Remote Control Door Lock Receiver																								V	V																																				
Y	2007	ALL	Body	Steering Column Lock Module																																																												
Y	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2008	ALL	Powertrain	Engine Control Module																																																												
Y	2008	ALL	Powertrain	Exhaust Flow Control Module																																																												
Y	2008	ALL	Powertrain	Transmission Control Module																																																												
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2008	ALL	Chassis	Electronic Suspension Control																																																												
Y	2008	ALL	Body	Body Control Module											V																																V															
Y	2008	ALL	Body	CD Changer																																																												
Y	2008	ALL	Body	Digital Radio Receiver																																																												
Y	2008	ALL	Body	Driver Door Module																																																												
Y	2008	ALL	Body	Driver Door Switch																																																												
Y	2008	ALL	Body	Driver Position Module																																																												
Y	2008	ALL	Body	Folding Top Module																		V																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Y	2008	ALL	Body	Head Up Display																																																										
Y	2008	ALL	Body	HVAC Control Module																					V																																					
Y	2008	ALL	Body	Instrument Panel Cluster																																																										
Y	2008	ALL	Body	Navigation Radio																																																										
Y	2008	ALL	Body	Passenger Door Module																																																										
Y	2008	ALL	Body	Radio																																																										
Y	2008	ALL	Body	Personal Audio Link Module																																																										
Y	2008	ALL	Body	Remote Control Door Lock Receiver																								V	V																																	
Y	2008	ALL	Body	Steering Column Lock Module																																																										
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																										
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																										
Y	2009	ALL	Chassis	Electronic Brake Control Module																													V																													
Y	2009	ALL	Chassis	Electronic Suspension Control																																																										
Y	2009	ALL	Body	Body Control Module											V																															V																
Y	2009	ALL	Body	CD Changer																																																										
Y	2009	ALL	Body	Digital Radio Receiver																																																										
Y	2009	ALL	Body	Driver Door Module																																																										
Y	2009	ALL	Body	Driver Door Switch																																																										
Y	2009	ALL	Body	Driver Position Module																																																										
Y	2009	ALL	Body	Folding Top Module																		V																																								
Y	2009	ALL	Body	Head Up Display																																																										
Y	2009	ALL	Body	HVAC Control Module																					V																																					
Y	2009	ALL	Body	Instrument Panel Cluster																																																										
Y	2009	ALL	Body	Navigation Radio																																																										
Y	2009	ALL	Body	Passenger Door Module																																																										
Y	2009	ALL	Body	Radio																																																										
Y	2009	ALL	Body	Personal Audio Link Module																																																										
Y	2009	ALL	Body	Remote Control Door Lock Receiver																								V	V																																	
Y	2009	ALL	Body	Steering Column Lock Module																																																										
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																										
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																										
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																										
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																										
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2010	ALL	Chassis	Electronic Brake Control Module																													V																													
Y	2010	ALL	Chassis	Electronic Suspension Control																																																										
Y	2010	ALL	Body	Body Control Module											V																															V																
Y	2010	ALL	Body	CD Changer																																																										
Y	2010	ALL	Body	Digital Radio Receiver																																																										
Y	2010	ALL	Body	Driver Door Module																																																										
Y	2010	ALL	Body	Driver Door Switch																																																										
Y	2010	ALL	Body	Driver Position Module																																																										
Y	2010	ALL	Body	Folding Top Module																		V																																								
Y	2010	ALL	Body	Head Up Display																																																										
Y	2010	ALL	Body	HVAC Control Module																					V																																					

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Y	2010	ALL	Body	Instrument Panel Cluster																																																										
Y	2010	ALL	Body	Navigation Radio																																																										
Y	2010	ALL	Body	Passenger Door Module																																																										
Y	2010	ALL	Body	Radio																																																										
Y	2010	ALL	Body	Personal Audio Link Module																																																										
Y	2010	ALL	Body	Remote Control Door Lock Receiver																								V	V																																	
Y	2010	ALL	Body	Steering Column Lock Module																																																										
Y	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																										
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																										
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																										
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																										
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2011	ALL	Chassis	Electronic Brake Control Module																													V																													
Y	2011	ALL	Chassis	Electronic Suspension Control																																																										
Y	2011	ALL	Body	Body Control Module										V																															V																	
Y	2011	ALL	Body	CD Changer																																																										
Y	2011	ALL	Body	Digital Radio Receiver																																																										
Y	2011	ALL	Body	Driver Door Module																																																										
Y	2011	ALL	Body	Driver Door Switch																																																										
Y	2011	ALL	Body	Driver Position Module																																																										
Y	2011	ALL	Body	Folding Top Module																		V																																								
Y	2011	ALL	Body	Head Up Display																																																										
Y	2011	ALL	Body	HVAC Control Module																					V																																					
Y	2011	ALL	Body	Instrument Panel Cluster																																																										
Y	2011	ALL	Body	Navigation Radio																																																										
Y	2011	ALL	Body	Passenger Door Module																																																										
Y	2011	ALL	Body	Radio																																																										
Y	2011	ALL	Body	Personal Audio Link Module																																																										
Y	2011	ALL	Body	Remote Control Door Lock Receiver																								V	V																																	
Y	2011	ALL	Body	Steering Column Lock Module																																																										
Y	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																										
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																										
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																										
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																										
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2012	ALL	Chassis	Electronic Brake Control Module																													V																													
Y	2012	ALL	Chassis	Electronic Suspension Control																																																										
Y	2012	ALL	Body	Body Control Module										V																															V																	
Y	2012	ALL	Body	CD Changer																																																										
Y	2012	ALL	Body	Digital Radio Receiver																																																										
Y	2012	ALL	Body	Driver Door Module																																																										
Y	2012	ALL	Body	Driver Door Switch																																																										
Y	2012	ALL	Body	Driver Position Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Y	2012	ALL	Body	Folding Top Module																		V																																								
Y	2012	ALL	Body	Head Up Display																																																										
Y	2012	ALL	Body	HVAC Control Module																					V																																						
Y	2012	ALL	Body	Instrument Panel Cluster																																																										
Y	2012	ALL	Body	Navigation Radio																																																										
Y	2012	ALL	Body	Passenger Door Module																																																										
Y	2012	ALL	Body	Radio																																																										
Y	2012	ALL	Body	Personal Audio Link Module																																																										
Y	2012	ALL	Body	Remote Control Door Lock Receiver																								V	V																																		
Y	2012	ALL	Body	Steering Column Lock Module																																																										
Y	2012	ALL	Body	Supplemental Inflatable Restraint											V																																															
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																											
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																											
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																											
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																											
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																											
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																											
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																											
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																											
Y	2013	ALL	Chassis	Electronic Brake Control Module																													V																															
Y	2013	ALL	Chassis	Electronic Suspension Control																																																											
Y	2013	ALL	Body	Body Control Module											V																																V															
Y	2013	ALL	Body	CD Changer																																																										
Y	2013	ALL	Body	Digital Radio Receiver																																																											
Y	2013	ALL	Body	Driver Door Module																																																											
Y	2013	ALL	Body	Driver Door Switch																																																											
Y	2013	ALL	Body	Driver Position Module																																																											
Y	2013	ALL	Body	Folding Top Module																		V																																									
Y	2013	ALL	Body	Head Up Display																																																											
Y	2013	ALL	Body	HVAC Control Module																					V																																						
Y	2013	ALL	Body	Instrument Panel Cluster																																																											
Y	2013	ALL	Body	Navigation Radio																																																											
Y	2013	ALL	Body	Passenger Door Module																																																											
Y	2013	ALL	Body	Radio																																																											
Y	2013	ALL	Body	Personal Audio Link Module																																																											
Y	2013	ALL	Body	Remote Control Door Lock Receiver																								V	V																																		
Y	2013	ALL	Body	Steering Column Lock Module																																																											
Y	2013	ALL	Body	Supplemental Inflatable Restraint											V																																															
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																											
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																											
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																											
Y	2014	Corvette	Powertrain	Chassis Control Module																																																											
Y	2014	Corvette	Chassis	Electronic Brake Control Module																																																											
Y	2014	Corvette	Chassis	Parking Brake Control Module																																																											
Y	2014	Corvette	Chassis	Power Steering Control Module																																																											
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																											
Y	2014	Corvette	Chassis	Suspension Control Module																																																											
Y	2014	Corvette	Body	Body Control Module Convertible																																																											
Y	2014	Corvette	Body	Body Control Module Coupe																																																											
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
Y	2014	Corvette	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Y	2014	Corvette	Body	Instrument Cluster																																																														
Y	2014	Corvette	Body	Radio/HVAC Control																																																														
Y	2014	Corvette	Body	Inside Rearview Mirror																																																														
Y	2014	Corvette	Body	Radio																																																														
Y	2014	Corvette	Body	Amplifier																																																														
Y	2014	Corvette	Body	Human Machine Interface Control Module																																																														
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																														
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																														
Y	2014	Corvette	Body	HVAC Control Module																																																														
Y	2014	Corvette	Body	Seat Memory Control Module - Passenger																																																														
Y	2014	Corvette	Body	Seat Memory Control Module - Driver																																																														
Y	2014	Corvette	Body	Folding Top Control Module																																																														
Y	2014	Corvette	Body	Keyless Entry Control Module																																																														
Y	2014	Corvette	Body	Steering Column Lock Control Module																																																														
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																														
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																														
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																														
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Automatic Transmission																																																														
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Manual Transmission																																																														
Y	2015	Corvette	Powertrain	6.2L LT4 Transmission Control Module																																																														
Y	2015	Corvette	Powertrain	Chassis Control Module																																																														
Y	2015	Corvette	Chassis	Electronic Brake Control Module																																																														
Y	2015	Corvette	Chassis	Parking Brake Control Module																																																														
Y	2015	Corvette	Chassis	Power Steering Control Module																																																														
Y	2015	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																														
Y	2015	Corvette	Chassis	Suspension Control Module																																																														
Y	2015	Corvette	Body	Body Control Module Convertible																																																														
Y	2015	Corvette	Body	Body Control Module Coupe																																																														
Y	2015	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
Y	2015	Corvette	Body	Passenger Presence Module																																																														
Y	2015	Corvette	Body	Instrument Cluster																																																														
Y	2015	Corvette	Body	Radio/HVAC Control																																																														
Y	2015	Corvette	Body	Vehicle Performance Data Recorder																																																														
Y	2015	Corvette	Body	Inside Rearview Mirror																																																														
Y	2015	Corvette	Body	Radio																																																														
Y	2015	Corvette	Body	Amplifier																																																														
Y	2015	Corvette	Body	Human Machine Interface Control Module																																																														
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																														
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																														
Y	2015	Corvette	Body	HVAC Control Module																																																														
Y	2015	Corvette	Body	Seat Memory Control Module - Passenger																																																														
Y	2015	Corvette	Body	Seat Memory Control Module - Driver																																																														
Y	2015	Corvette	Body	Folding Top Control Module																																																														
Y	2015	Corvette	Body	Keyless Entry Control Module																																																														
Y	2015	Corvette	Body	Steering Column Lock Control Module																																																														
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																														
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																														
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Automatic Transmission																																																														
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Manual Transmission																																																														
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Y	2016	Corvette	Powertrain	Rear Differential Clutch Control Module																																																												
Y	2016	Corvette	Chassis	Electronic Brake Control Module																																																													
Y	2016	Corvette	Chassis	Parking Brake Control Module																																																												
Y	2016	Corvette	Chassis	Power Steering Control Module																																																												
Y	2016	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																												
Y	2016	Corvette	Chassis	Suspension Control Module																																																												
Y	2016	Corvette	Body	Body Control Module																																																												
Y	2016	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
Y	2016	Corvette	Body	Passenger Presence Module																																																												
Y	2016	Corvette	Body	Instrument Cluster																																																												
Y	2016	Corvette	Body	Radio/HVAC Control																																																												
Y	2016	Corvette	Body	Vehicle Performance Data Recorder																																																												
Y	2016	Corvette	Body	Video Processing Control Module																																																												
Y	2016	Corvette	Body	Inside Rearview Mirror																																																												
Y	2016	Corvette	Body	Radio																																																												
Y	2016	Corvette	Body	Amplifier																																																												
Y	2016	Corvette	Body	Human Machine Interface Control Module																																																												
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																												
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																												
Y	2016	Corvette	Body	HVAC Control Module																																																												
Y	2016	Corvette	Body	Liftgate Control Module																																																												
Y	2016	Corvette	Body	Seat Memory Control Module - Passenger																																																												
Y	2016	Corvette	Body	Seat Memory Control Module - Driver																																																												
Y	2016	Corvette	Body	Folding Top Control Module																																																												
Y	2016	Corvette	Body	Keyless Entry Control Module																																																												
Y	2016	Corvette	Body	Steering Column Lock Control Module																																																												
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																												
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																												
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																												
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																												
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																												
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																												
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																												
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																												
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																												
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																												
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																												
Y	2016	Cruze	Chassis	Electronic Brake Control Module																																																												
Y	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																												
Y	2016	Cruze	Chassis	Power Steering Control Module																																																												
Y	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
Y	2016	Cruze	Body	Body Control Module																																																												
Y	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
Y	2016	Cruze	Body	Passenger Presence Module																																																												
Y	2016	Cruze	Body	Instrument Cluster																																																												
Y	2016	Cruze	Body	Radio Controls																																																												
Y	2016	Cruze	Body	HVAC Controls																																																												
Y	2016	Cruze	Body	Trailer Interface Control Module																																																												
Y	2016	Cruze	Body	Radio Base (IO3 IO7)																																																												
Y	2016	Cruze	Body	Radio (IOA)																																																												
Y	2016	Cruze	Body	Radio (IOB)																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Y	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																												
Y	2016	Cruze	Body	Amplifier																																																												
Y	2016	Cruze	Body	Multimedia Player Interface Module																																																												
Y	2016	Cruze	Body	Human Machine Interface Control Module																																																												
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																												
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
Y	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
Y	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																												
Y	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																												
Y	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																												
Y	2016	Cruze	Body	Keyless Entry Control Module																																																												
Y	2016	Cruze	Body	Right Side Object Detection Control Module																																																												
Y	2016	Cruze	Body	Left Side Object Detection Control Module																																																												
Y	2016	Cruze	Body	Parking Assist Control Module																																																												
Y	2016	Cruze	Body	Frontview Camera Module																																																												
Y	2016	Cruze	Body	Steering Column Lock Control Module																																																												
Y	2016	Cruze	Body	Long Range Radar Sensor Module																																																												
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																												
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Transmission Control Module																																																												
Z	2004	ALL	Chassis	Electronic Brake Control Module																																																												
Z	2004	ALL	Chassis	Power Steering Control Module																																										V																	
Z	2004	ALL	Body	Body Control Module											V																					V									V																	
Z	2004	ALL	Body	Digital Radio Receiver																																																											
Z	2004	ALL	Body	HVAC Control Module																					V																																						
Z	2004	ALL	Body	Instrument Panel Cluster																																																											
Z	2004	ALL	Body	Radio																																																											
Z	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2004	ALL	Body	Theft Deterrent Module																																																											
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																											
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																											
Z	2005	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																											
Z	2005	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2005	ALL	Chassis	Power Steering Control Module																																										V																	
Z	2005	ALL	Body	Body Control Module											V																					V									V																	
Z	2005	ALL	Body	Digital Radio Receiver																																																											
Z	2005	ALL	Body	HVAC Control Module																					V																																						
Z	2005	ALL	Body	Instrument Panel Cluster																																																											
Z	2005	ALL	Body	Radio																																																											
Z	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2005	ALL	Body	Theft Deterrent Module																																																											
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																											
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																											
Z	2006	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																											
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																											
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																											
Z	2006	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2006	ALL	Chassis	Power Steering Control Module																																										V																	
Z	2006	ALL	Body	Body Control Module											V																					V									V																	
Z	2006	ALL	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Z	2006	ALL	Body	HVAC Control Module																					V																																						
Z	2006	ALL	Body	Instrument Panel Cluster																																																												
Z	2006	ALL	Body	Radio																																																											
Z	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2006	ALL	Body	Theft Deterrent Module																																																											
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																								V																		
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																											
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																											
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																											
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																											
Z	2007	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2007	ALL	Chassis	Power Steering Control Module																																									V																		
Z	2007	ALL	Body	Body Control Module											V																					V																											
Z	2007	ALL	Body	Digital Radio Receiver																																																											
Z	2007	ALL	Body	Disc Player and Video Display																																																											
Z	2007	ALL	Body	HVAC Control Module																					V																																							
Z	2007	ALL	Body	Instrument Panel Cluster																																																												
Z	2007	ALL	Body	Radio																																																											
Z	2007	ALL	Body	Remote Control Door Lock Receiver																																																											
Z	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2007	ALL	Body	Theft Deterrent Module																																																											
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																								V																		
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																											
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																					V																						
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																											
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																											
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																											
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								V																		
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
Z	2008	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2008	ALL	Chassis	Power Steering Control Module																																									V																		
Z	2008	ALL	Body	Body Control Module Classic											V																					V																											
Z	2008	ALL	Body	Body Control Module Malibu											V																					V		V																									
Z	2008	ALL	Body	Digital Radio Receiver																																																											
Z	2008	ALL	Body	Disc Player and Video Display																																																											
Z	2008	ALL	Body	HVAC Control Module Classic																					V																																					
Z	2008	ALL	Body	HVAC Control Module Malibu																					V																																					
Z	2008	ALL	Body	Instrument Panel Cluster Classic																																																											
Z	2008	ALL	Body	Instrument Panel Cluster Malibu																																																											
Z	2008	ALL	Body	Radio																																																											
Z	2008	ALL	Body	Remote Control Door Lock Receiver																																																											
Z	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2008	ALL	Body	Theft Deterrent Module																																																											
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																											
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																											
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																											
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump																																																											
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump																																																											
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Without Tap Shift																																																											
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																												
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																												
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								V																			
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
Z	2009	ALL	Chassis	Electronic Brake Control Module																																																												
Z	2009	ALL	Chassis	Power Steering Control Module																																									V																			
Z	2009	ALL	Body	Body Control Module											V																					V		V																										
Z	2009	ALL	Body	Digital Radio Receiver																																																											
Z	2009	ALL	Body	Disc Player and Video Display																																																												
Z	2009	ALL	Body	HVAC Control Module																					V																																							
Z	2009	ALL	Body	Instrument Panel Cluster																																																												
Z	2009	ALL	Body	Personal Audio Link Module																																																												
Z	2009	ALL	Body	Radio																																																											
Z	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2009	ALL	Body	Theft Deterrent Module																																																											
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																											
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																											
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																											
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Engine Control Module																																																											
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 6 Speed																																																											
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 4 Speed																																																											
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																											
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																											
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								V																			
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
Z	2010	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2010	ALL	Chassis	Power Steering Control Module																																									V																			
Z	2010	ALL	Body	Body Control Module											V																					V		V																										
Z	2010	ALL	Body	Digital Radio Receiver																																																											
Z	2010	ALL	Body	HVAC Control Module																					V																																							
Z	2010	ALL	Body	Instrument Panel Cluster																																																												
Z	2010	ALL	Body	Personal Audio Link Module																																																												
Z	2010	ALL	Body	Radio																																																											
Z	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2010	ALL	Body	Theft Deterrent Module																																																											
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																											
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																											
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																											
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																											
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								V																			
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
Z	2011	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2011	ALL	Chassis	Power Steering Control Module																																									V																			
Z	2011	ALL	Body	Body Control Module											V																					V		V																										
Z	2011	ALL	Body	Digital Radio Receiver																																																											
Z	2011	ALL	Body	HVAC Control Module																					V																																						
Z	2011	ALL	Body	Instrument Panel Cluster																																																											
Z	2011	ALL	Body	Personal Audio Link Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Z	2011	ALL	Body	Radio																																																												
Z	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
Z	2011	ALL	Body	Theft Deterrent Module																																																												
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Engine Control Module																																																												
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Transmission Control Module																																																												
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																												
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																												
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																												
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																												
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																									V																			
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
Z	2012	Malibu (Seventh Gen)	Chassis	Electronic Brake Control Module																																																												
Z	2012	Malibu (Seventh Gen)	Chassis	Power Steering Control Module																																										V																		
Z	2012	Malibu (Seventh Gen)	Body	Body Control Module											V																					V		V																										
Z	2012	Malibu (Seventh Gen)	Body	Digital Radio Receiver																																																												
Z	2012	Malibu (Seventh Gen)	Body	HVAC Control Module																					V																																							
Z	2012	Malibu (Seventh Gen)	Body	Instrument Panel Cluster																																																												
Z	2012	Malibu (Seventh Gen)	Body	Personal Audio Link Module																																																												
Z	2012	Malibu (Seventh Gen)	Body	Radio																																																												
Z	2012	Malibu (Seventh Gen)	Body	Supplemental Inflatable Restraint																																																												
Z	2012	Malibu (Seventh Gen)	Body	Theft Deterrent Module																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Fuel Injector Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Transmission Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Transmission Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Fuel Pump Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Transmission Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																												V																
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																												V																
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Fuel Pump Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Powertrain	Rear Differential Clutch Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Chassis	Electronic Brake Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Chassis	Parking Brake Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
Z	2012	Malibu (Eighth Gen)	Chassis	Power Steering Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Chassis	Steering Wheel Angle Sensor Module																																																												
Z	2012	Malibu (Eighth Gen)	Chassis	Suspension Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																												
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																												
Z	2012	Malibu (Eighth Gen)	Body	Passenger Presence Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Z	2012	Malibu (Eighth Gen)	Body	Instrument Cluster																																																															
Z	2012	Malibu (Eighth Gen)	Body	Head-Up Display Module																																																															
Z	2012	Malibu (Eighth Gen)	Body	Headlamp Control Module																																																															
Z	2012	Malibu (Eighth Gen)	Body	Radio																																																															
Z	2012	Malibu (Eighth Gen)	Body	Digital Radio Receiver Control Module																																																															
Z	2012	Malibu (Eighth Gen)	Body	Multimedia Player Interface Module																																																															
Z	2012	Malibu (Eighth Gen)	Body	Mobile Telephone Control Module																																																															
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Dual (CJ2)																																																															
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Single (C68)																																																															
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Manual Single (C67)																																																															
Z	2012	Malibu (Eighth Gen)	Body	Rear Seat Heating Control Module																																																															
Z	2012	Malibu (Eighth Gen)	Body	Keyless Entry Control Module																																																															
Z	2012	Malibu (Eighth Gen)	Body	Right Side Object Detection Control Module																																																															
Z	2012	Malibu (Eighth Gen)	Body	Left Side Object Detection Control Module																																																															
Z	2012	Malibu (Eighth Gen)	Body	Parking Assist Control Module																																																															
Z	2012	Malibu (Eighth Gen)	Body	Vehicle Direction Camera Control Module																																																															
Z	2012	Malibu (Eighth Gen)	Body	Steering Column Lock Control Module																																																															
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Engine Control Module																																																															
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Transmission Control Module																																																															
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Engine Control Module																																																															
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 1																																																															
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 2																																																															
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module																																																															
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 6 Speed (MNM)																																																															
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 8 Speed (MRC)																																																															
Z	2016	Malibu	Chassis	Electronic Brake Control Module																																																															
Z	2016	Malibu	Chassis	Brake Booster Control Module																																																															
Z	2016	Malibu	Chassis	Power Steering Control Module																																																															
Z	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																															
Z	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																															
Z	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
Z	2016	Malibu	Body	Passenger Presence Module																																																															
Z	2016	Malibu	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																															
Z	2016	Malibu	Body	Instrument Cluster Enhanced Monochrome Driver Info Center (UDC)																																																															
Z	2016	Malibu	Body	Radio Controls																																																															
Z	2016	Malibu	Body	HVAC Controls																																																															
Z	2016	Malibu	Body	Active Safety Control Module																																																															
Z	2016	Malibu	Body	Headlamp Control Module																																																															
Z	2016	Malibu	Body	Radio Base																																																															
Z	2016	Malibu	Body	Radio (IOA)																																																															
Z	2016	Malibu	Body	Radio Uplevel (IO4 IO5 IO6)																																																															
Z	2016	Malibu	Body	Amplifier																																																															
Z	2016	Malibu	Body	Human Machine Interface Control Module																																																															
Z	2016	Malibu	Body	Navigation Control Module																																																															
Z	2016	Malibu	Body	Mobile Telephone Control Module																																																															
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																															
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																															
Z	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																															
Z	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																															
Z	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																															
Z	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
Z	2016	Malibu	Body	Electric A/C Compressor Control Module																																																															
Z	2016	Malibu	Body	Seat Memory Control Module - Driver																																																															
Z	2016	Malibu	Body	Keyless Entry Control Module																																																															
Z	2016	Malibu	Body	Right Side Object Detection Control Module																																																															
Z	2016	Malibu	Body	Left Side Object Detection Control Module																																																															
Z	2016	Malibu	Body	Parking Assist Control Module																																																															
Z	2016	Malibu	Body	Frontview Camera Module																																																															
Z	2016	Malibu	Body	Frontview Camera Module																																																															
Z	2016	Malibu	Body	Steering Column Lock Control Module																																																															
Z	2016	Malibu	Body	Long Range Radar Sensor Module																																																															
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																															
1	2013	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																															
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																															
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	2.0L LTD Fuel Pump Control Module																																																															
1	2013	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																															
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	(X) 2.0L LTG Fuel Pump Control Module																																																															
1	2013	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																															
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																															
1	2013	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																															
1	2013	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																															
1	2013	Malibu	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																															
1	2013	Malibu	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																																																															
1	2013	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																															
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	(A) 2.5L LCV Fuel Pump Control Module																																																															
1	2013	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																															
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																															
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																															
1	2013	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																															
1	2013	Malibu	Chassis	Electronic Brake Control Module																																																															
1	2013	Malibu	Chassis	Parking Brake Control Module																																																															
1	2013	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																															
1	2013	Malibu	Chassis	Power Steering Control Module																																																															
1	2013	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																															
1	2013	Malibu	Chassis	Suspension Control Module																																																															
1	2013	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																															
1	2013	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																															
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																												
1	2013	Malibu	Body	Passenger Presence Module																																																												
1	2013	Malibu	Body	Instrument Cluster																																																												
1	2013	Malibu	Body	Headlamp Control Module																																																												
1	2013	Malibu	Body	Radio																																																												
1	2013	Malibu	Body	Digital Radio Receiver Control Module																																																												
1	2013	Malibu	Body	Multimedia Player Interface Module																																																												
1	2013	Malibu	Body	Mobile Telephone Control Module																																																												
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2013	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																												
1	2013	Malibu	Body	HVAC Control Module Auto Single (C68)																																																												
1	2013	Malibu	Body	HVAC Control Module Manual Single (C67)																																																												
1	2013	Malibu	Body	Rear Seat Heating Control Module																																																												
1	2013	Malibu	Body	Keyless Entry Control Module																																																												
1	2013	Malibu	Body	Parking Assist Control Module																																																												
1	2013	Malibu	Body	Vehicle Direction Camera Control Module																																																												
1	2013	Malibu	Body	Steering Column Lock Control Module																																																												
1	2013	Malibu	Body	Battery Energy Control Module																																																												
1	2014	Impala	Powertrain	(R) 2.4L LUK Engine Control Module																																																												
1	2014	Impala	Powertrain	(R) 2.4L LUK Transmission Control Module																																																												
1	2014	Impala	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																												
1	2014	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																												
1	2014	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																												
1	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
1	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																												
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																												
1	2014	Impala	Chassis	Electronic Brake Control Module																																																												
1	2014	Impala	Chassis	Distance Sensing Cruise Control Module																																																												
1	2014	Impala	Chassis	Parking Brake Control Module																																																												
1	2014	Impala	Chassis	Power Steering Control Module																																																												
1	2014	Impala	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2014	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
1	2014	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
1	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	Impala	Body	Passenger Presence Module																																																												
1	2014	Impala	Body	Instrument Cluster																																																												
1	2014	Impala	Body	Radio Control																																																												
1	2014	Impala	Body	HVAC Control																																																												
1	2014	Impala	Body	Radio																																																												
1	2014	Impala	Body	Amplifier																																																												
1	2014	Impala	Body	Human Machine Interface Control Module																																																												
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Impala	Body	HVAC Control Module																																																												
1	2014	Impala	Body	Keyless Entry Control Module																																																												
1	2014	Impala	Body	Right Side Object Detection Control Module																																																												
1	2014	Impala	Body	Left Side Object Detection Control Module																																																												
1	2014	Impala	Body	Parking Assist Control Module																																																												
1	2014	Impala	Body	Frontview Camera Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2014	Impala	Body	Steering Column Lock Control Module																																																														
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																														
1	2014	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																														
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																														
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																														
1	2014	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																														
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																														
1	2014	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																														
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																										V																		
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																										V																		
1	2014	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																														
1	2014	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																														
1	2014	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																														
1	2014	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																														
1	2014	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																														
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																														
1	2014	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																														
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																														
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																														
1	2014	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
1	2014	Malibu	Chassis	Electronic Brake Control Module																																																														
1	2014	Malibu	Chassis	Parking Brake Control Module																																																														
1	2014	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																														
1	2014	Malibu	Chassis	Power Steering Control Module																																																														
1	2014	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																														
1	2014	Malibu	Chassis	Suspension Control Module																																																														
1	2014	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
1	2014	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																														
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																														
1	2014	Malibu	Body	Passenger Presence Module																																																														
1	2014	Malibu	Body	Instrument Cluster																																																														
1	2014	Malibu	Body	Headlamp Control Module																																																														
1	2014	Malibu	Body	Radio																																																														
1	2014	Malibu	Body	Digital Radio Receiver Control Module																																																														
1	2014	Malibu	Body	Multimedia Player Interface Module																																																														
1	2014	Malibu	Body	Mobile Telephone Control Module																																																														
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																														
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																														
1	2014	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																														
1	2014	Malibu	Body	HVAC Control Module Auto Single (C68)																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2014	Malibu	Body	HVAC Control Module Manual Single (C67)																																																														
1	2014	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																														
1	2014	Malibu	Body	Rear Seat Heating Control Module																																																														
1	2014	Malibu	Body	Keyless Entry Control Module																																																														
1	2014	Malibu	Body	Left Side Object Detection Control Module																																																														
1	2014	Malibu	Body	Parking Assist Control Module																																																														
1	2014	Malibu	Body	Frontview Camera Module																																																														
1	2014	Malibu	Body	Steering Column Lock Control Module																																																														
1	2015	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																														
1	2015	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																														
1	2015	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																														
1	2015	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																														
1	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
1	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																														
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																														
1	2015	Impala	Chassis	Electronic Brake Control Module																																																														
1	2015	Impala	Chassis	Distance Sensing Cruise Control Module																																																														
1	2015	Impala	Chassis	Parking Brake Control Module																																																														
1	2015	Impala	Chassis	Power Steering Control Module																																																														
1	2015	Impala	Chassis	Power Steering Control Module																																																														
1	2015	Impala	Chassis	Steering Wheel Angle Sensor Module																																																														
1	2015	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
1	2015	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
1	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
1	2015	Impala	Body	Passenger Presence Module																																																															
1	2015	Impala	Body	Instrument Cluster																																																															
1	2015	Impala	Body	Radio Control																																																															
1	2015	Impala	Body	HVAC Control																																																															
1	2015	Impala	Body	Radio																																																															
1	2015	Impala	Body	Amplifier																																																															
1	2015	Impala	Body	Human Machine Interface Control Module																																																															
1	2015	Impala	Body	Telematics Communication Interface Control Module																																																															
1	2015	Impala	Body	HVAC Control Module																																																															
1	2015	Impala	Body	Keyless Entry Control Module																																																															
1	2015	Impala	Body	Right Side Object Detection Control Module																																																															
1	2015	Impala	Body	Left Side Object Detection Control Module																																																															
1	2015	Impala	Body	Parking Assist Control Module																																																															
1	2015	Impala	Body	Frontview Camera Module																																																															
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																															
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																															
1	2015	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																															
1	2015	Malibu	Powertrain	2.0L LBN Chassis Control Module																																																															
1	2015	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																															
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																															
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																															
1	2015	Malibu	Powertrain	2.0L LBS Chassis Control Module																																																															
1	2015	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																															
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																															
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																															
1	2015	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2015	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																													
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																													
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																													
1	2015	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																													
1	2015	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																													
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																											V																	
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																											V																	
1	2015	Malibu	Powertrain	2.4L LE9 Chassis Control Module																																																												
1	2015	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																													
1	2015	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																													
1	2015	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																													
1	2015	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																													
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																													
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																													
1	2015	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																													
1	2015	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																													
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Automatic Transmission																																																													
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Manual Transmission																																																													
1	2015	Malibu	Powertrain	3.0L LFW Chassis Control Module																																																													
1	2015	Malibu	Powertrain	3.0L LFW Transmission Control Module																																																													
1	2015	Malibu	Powertrain	Rear Differential Clutch Control Module																																																													
1	2015	Malibu	Chassis	Electronic Brake Control Module																																																													
1	2015	Malibu	Chassis	Parking Brake Control Module																																																												
1	2015	Malibu	Chassis	Power Steering Control Module																																																												
1	2015	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2015	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
1	2015	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
1	2015	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2015	Malibu	Body	Passenger Presence Module																																																												
1	2015	Malibu	Body	Instrument Cluster																																																												
1	2015	Malibu	Body	Headlamp Control Module																																																												
1	2015	Malibu	Body	Radio																																																												
1	2015	Malibu	Body	Digital Radio Receiver Control Module																																																												
1	2015	Malibu	Body	Multimedia Player Interface Module																																																												
1	2015	Malibu	Body	Mobile Telephone Control Module																																																												
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																												
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2015	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																												
1	2015	Malibu	Body	HVAC Control Module Auto Single (C68)																																																												
1	2015	Malibu	Body	HVAC Control Module Manual Single (C67)																																																												
1	2015	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																												
1	2015	Malibu	Body	Front Seat Heating Control Module																																																												
1	2015	Malibu	Body	Rear Seat Heating Control Module																																																												
1	2015	Malibu	Body	Keyless Entry Control Module																																																												
1	2015	Malibu	Body	Left Side Object Detection Control Module																																																												
1	2015	Malibu	Body	Parking Assist Control Module																																																												
1	2015	Malibu	Body	Frontview Camera Module																																																												
1	2015	Malibu	Body	Steering Column Lock Control Module																																																												
1	2015	Malibu (LSG)	Powertrain	1.6L LLU Engine Control Module																																													V		V				V	V		
1	2015	Malibu (LSG)	Powertrain	Transmission Control Module																																																											
1	2015	Malibu (LSG)	Powertrain	Rear Differential Clutch Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2015	Malibu (LSG)	Chassis	Electronic Brake Control Module																																																														
1	2015	Malibu (LSG)	Chassis	Parking Brake Control Module																																																														
1	2015	Malibu (LSG)	Chassis	Steering Wheel Angle Sensor Module																																																														
1	2015	Malibu (LSG)	Chassis	Suspension Control Module																																																														
1	2015	Malibu (LSG)	Body	Body Control Module																																																														
1	2015	Malibu (LSG)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
1	2015	Malibu (LSG)	Body	Instrument Cluster																																																														
1	2015	Malibu (LSG)	Body	Headlamp Control Module																																																														
1	2015	Malibu (LSG)	Body	Radio																																																														
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 9.7																																																														
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 10																																																														
1	2015	Malibu (LSG)	Body	HVAC Control Module																																																														
1	2015	Malibu (LSG)	Body	Front Seat Heating Control Module																																																														
1	2015	Malibu (LSG)	Body	Keyless Entry Control Module																																																														
1	2015	Malibu (LSG)	Body	Left Side Object Detection Control Module																																																														
1	2015	Malibu (LSG)	Body	Parking Assist Control Module																																																														
1	2015	Malibu (LSG)	Body	Frontview Camera Module																																																														
1	2015	Malibu (LSG)	Body	Steering Column Lock Control Module																																																														
1	2016	Impala	Powertrain	(A) 2.5L LCV Engine Control Module																																																														
1	2016	Impala	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														
1	2016	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																														
1	2016	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																														
1	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
1	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
1	2016	Impala	Powertrain	Chassis Control Module																																																														
1	2016	Impala	Chassis	Electronic Brake Control Module																																																														
1	2016	Impala	Chassis	Distance Sensing Cruise Control Module																																																														
1	2016	Impala	Chassis	Parking Brake Control Module																																																														
1	2016	Impala	Chassis	Power Steering Control Module																																																														
1	2016	Impala	Chassis	Power Steering Control Module																																																														
1	2016	Impala	Chassis	Steering Wheel Angle Sensor Module																																																														
1	2016	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
1	2016	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
1	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
1	2016	Impala	Body	Passenger Presence Module																																																															
1	2016	Impala	Body	Instrument Cluster																																																														
1	2016	Impala	Body	Radio Control																																																														
1	2016	Impala	Body	HVAC Control																																																														
1	2016	Impala	Body	Radio																																																														
1	2016	Impala	Body	Amplifier																																																														
1	2016	Impala	Body	Human Machine Interface Control Module																																																														
1	2016	Impala	Body	Navigation Control Module																																																														
1	2016	Impala	Body	Telematics Communication Interface Control Module																																																														
1	2016	Impala	Body	HVAC Control Module																																																														
1	2016	Impala	Body	Seat Memory Control Module - Driver																																																														
1	2016	Impala	Body	Keyless Entry Control Module																																																														
1	2016	Impala	Body	Right Side Object Detection Control Module																																																														
1	2016	Impala	Body	Left Side Object Detection Control Module																																																														
1	2016	Impala	Body	Parking Assist Control Module																																																														
1	2016	Impala	Body	Frontview Camera Module																																																														
1	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																											V													
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																											V													
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																								
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
1	2016	Malibu	Powertrain	Fuel Injector Control Module																																																								
1	2016	Malibu	Powertrain	Chassis Control Module																																																								
1	2016	Malibu	Chassis	Electronic Brake Control Module																																																								
1	2016	Malibu	Chassis	Parking Brake Control Module																																																								
1	2016	Malibu	Chassis	Power Steering Control Module																																																								
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2016	Malibu	Body	Passenger Presence Module																																																								
1	2016	Malibu	Body	Instrument Cluster																																																								
1	2016	Malibu	Body	Headlamp Control Module																																																								
1	2016	Malibu	Body	Radio																																																								
1	2016	Malibu	Body	Digital Radio Receiver Control Module																																																								
1	2016	Malibu	Body	Multimedia Player Interface Module																																																								
1	2016	Malibu	Body	Mobile Telephone Control Module																																																								
1	2016	Malibu	Body	Telematics Communication Interface Control Module																																																								
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																								
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																								
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																								
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																								
1	2016	Malibu	Body	Seat Memory Control Module																																																								
1	2016	Malibu	Body	Front Seat Heating Control Module																																																								
1	2016	Malibu	Body	Rear Seat Heating Control Module																																																								
1	2016	Malibu	Body	Keyless Entry Control Module																																																								
1	2016	Malibu	Body	Left Side Object Detection Control Module																																																								
1	2016	Malibu	Body	Parking Assist Control Module																																																								
1	2016	Malibu	Body	Frontview Camera Module																																																								

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2005	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																											
A	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
A	2005	ALL	Powertrain	Transmission Control Module																																																												
A	2005	ALL	Chassis	Power Steering Control Module																																																												
A	2005	ALL	Chassis	Anti-lock Brake System																																																												
A	2005	ALL	Body	Body Control Module																																																												
A	2005	ALL	Body	Digital Radio Receiver																																																												
A	2005	ALL	Body	Instrument Panel																																																												
A	2005	ALL	Body	Radio																																																												
A	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
A	2006	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																												
A	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
A	2006	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																												
A	2006	ALL	Powertrain	Transmission Control Module																																																												
A	2006	ALL	Chassis	Power Steering Control Module																																																												
A	2006	ALL	Chassis	Anti-lock Brake System																																																												
A	2006	ALL	Body	Body Control Module																																																												
A	2006	ALL	Body	Digital Radio Receiver																																																												
A	2006	ALL	Body	Instrument Panel																																																												
A	2006	ALL	Body	Radio																																																												
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
A	2006	ALL	Body	Theft Deterrent Module																																																												
A	2007	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																												
A	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
A	2007	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																												
A	2007	ALL	Powertrain	Transmission Control Module																																																												
A	2007	ALL	Chassis	Power Steering Control Module																																																												
A	2007	ALL	Chassis	Electronic Brake Control Module																																																												
A	2007	ALL	Body	Body Control Module																																																												
A	2007	ALL	Body	Digital Radio Receiver																																																												
A	2007	ALL	Body	Instrument Panel Cluster																																																												
A	2007	ALL	Body	Passenger Presence System																																																												
A	2007	ALL	Body	Personal Audio Link Module																																																												
A	2007	ALL	Body	Radio																																																												
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
A	2007	ALL	Body	Theft Deterrent Module																																																												
A	2008	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																												
A	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
A	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																												
A	2008	ALL	Powertrain	Transmission Control Module																																																												
A	2008	ALL	Chassis	Power Steering Control Module																																																												
A	2008	ALL	Chassis	Electronic Brake Control Module with VSES																																																												
A	2008	ALL	Chassis	Electronic Brake Control Module without VSES																																																												
A	2008	ALL	Body	Body Control Module																																																												
A	2008	ALL	Body	Digital Radio Receiver																																																												
A	2008	ALL	Body	Instrument Panel Cluster																																																												
A	2008	ALL	Body	Passenger Presence System																																																												
A	2008	ALL	Body	Personal Audio Link Module																																																												
A	2008	ALL	Body	Radio																																																												
A	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
A	2008	ALL	Body	Theft Deterrent Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2009	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																												
A	2009	ALL	Powertrain	(H)2.2L L4 LAP Engine Control Module																																																													
A	2009	ALL	Powertrain	Transmission Control Module																																																													
A	2009	ALL	Chassis	Power Steering Control Module																																																													
A	2009	ALL	Chassis	Electronic Brake Control Module with VSES																																																													
A	2009	ALL	Chassis	Electronic Brake Control Module without VSES																																																													
A	2009	ALL	Body	Body Control Module																																																													
A	2009	ALL	Body	Digital Radio Receiver																																																													
A	2009	ALL	Body	Instrument Panel Cluster																																																													
A	2009	ALL	Body	Passenger Presence System																																																													
A	2009	ALL	Body	Personal Audio Link Module																																																													
A	2009	ALL	Body	Radio																																																													
A	2009	ALL	Body	Supplemental Inflatable Restraint																																																													
A	2009	ALL	Body	Theft Deterrent Module																																																													
A	2010	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																													
A	2010	ALL	Powertrain	(5)2.2L L4 LAP Engine Control Module																																																													
A	2010	ALL	Powertrain	Transmission Control Module																																																													
A	2010	ALL	Chassis	Power Steering Control Module																																																													
A	2010	ALL	Chassis	Electronic Brake Control Module with VSES																																																													
A	2010	ALL	Chassis	Electronic Brake Control Module without VSES																																																													
A	2010	ALL	Body	Body Control Module																																																													
A	2010	ALL	Body	Digital Radio Receiver																																																													
A	2010	ALL	Body	Driver Information Center																																																												
A	2010	ALL	Body	Instrument Panel Cluster																																																													
A	2010	ALL	Body	Passenger Presence System																																																													
A	2010	ALL	Body	Personal Audio Link Module																																																													
A	2010	ALL	Body	Radio																																																													
A	2010	ALL	Body	Supplemental Inflatable Restraint																																																													
A	2010	ALL	Body	Theft Deterrent Module																																																													
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																													
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
A	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																													
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																													
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																													
A	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																													
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																													
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																													
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																													
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																													
A	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																													
A	2012	Cobalt	Chassis	Electronic Brake Control Module																																																													
A	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																													
A	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																													
A	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2012	Cobalt	Body	Body Control Module																																																													
A	2012	Cobalt	Body	Passenger Presence Module																																																													
A	2012	Cobalt	Body	Instrument Cluster																																																													
A	2012	Cobalt	Body	Radio																																																													
A	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																													
A	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																													
A	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
A	2012	Cobalt	Body	Front Seat Heating Control Module																																																												
A	2012	Cobalt	Body	Parking Assist Control Module																																																												
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
A	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
A	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
A	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
A	2013	Cobalt	Chassis	Electronic Brake Control Module																																																												
A	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2013	Cobalt	Body	Body Control Module																																																												
A	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2013	Cobalt	Body	Instrument Cluster																																																												
A	2013	Cobalt	Body	Radio																																																											
A	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																												
A	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												
A	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
A	2013	Cobalt	Body	Front Seat Heating Control Module																																																												
A	2013	Cobalt	Body	Parking Assist Control Module																																																												
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																												
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																												
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
A	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
A	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
A	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
A	2014	Cobalt	Chassis	Electronic Brake Control Module																																																												
A	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2014	Cobalt	Body	Body Control Module																																																												
A	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2014	Cobalt	Body	Instrument Cluster																																																												
A	2014	Cobalt	Body	Radio																																																											
A	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
A	2014	Cobalt	Body	Front Seat Heating Control Module																																																												
A	2014	Cobalt	Body	Parking Assist Control Module																																																												
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
A	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
A	2015	Cobalt	Chassis	Electronic Brake Control Module																																																												
A	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2015	Cobalt	Body	Body Control Module																																																												
A	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2015	Cobalt	Body	Instrument Cluster																																																												
A	2015	Cobalt	Body	Radio																																																											
A	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																												
A	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												
A	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
A	2015	Cobalt	Body	Front Seat Heating Control Module																																																												
A	2015	Cobalt	Body	Parking Assist Control Module																																																												
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
A	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
A	2016	Cobalt	Chassis	Electronic Brake Control Module																																																												
A	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2016	Cobalt	Body	Body Control Module																																																												
A	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2016	Cobalt	Body	Instrument Cluster																																																												
A	2016	Cobalt	Body	Radio Other																																																												
A	2016	Cobalt	Body	Radio (IOB)																																																												
A	2016	Cobalt	Body	Radio (UF7)																																																												
A	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
A	2016	Cobalt	Body	Front Seat Heating Control Module																																																												
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																												
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																												
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V																																																											
B	2010	Beat	Powertrain	Transmission Control Module																																																												
B	2010	Beat	Chassis	Electronic Brake Control Module																																																												
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												
B	2010	Beat	Chassis	Power Steering Control Module																																																												
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module																																																												
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
B	2010	Beat	Body	Instrument Cluster																																																												
B	2010	Beat	Body	Keyless Entry Control Module			V	V																																																								
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																												
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																												
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V																																																											
B	2011	Beat	Powertrain	Transmission Control Module																																																												
B	2011	Beat	Chassis	Electronic Brake Control Module																																																												
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												
B	2011	Beat	Chassis	Electric Power Steering Control Module																																																												
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module																																																												
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
B	2011	Beat	Body	Instrument Cluster																																																												
B	2011	Beat	Body	Keyless Entry Control Module			V	V																																																								
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module																																																												
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V																																																											
B	2012	Beat	Powertrain	Transmission Control Module																																																												
B	2012	Beat	Chassis	Electronic Brake Control Module																																																												
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												
B	2012	Beat	Chassis	Electric Power Steering Control Module																																																												
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module																																																												
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
B	2012	Beat	Body	Instrument Cluster																																																												
B	2012	Beat	Body	Keyless Entry Control Module			V	V																																																								
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module																																																												
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V																																																										
B	2013	Beat	Powertrain	Transmission Control Module																																																												
B	2013	Beat	Chassis	Electronic Brake Control Module																																																												
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												
B	2013	Beat	Chassis	Electric Power Steering Control Module																																																												
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module																																																												
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
B	2013	Beat	Body	Instrument Cluster																																																												
B	2013	Beat	Body	Keyless Entry Control Module			V	V																																																								
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module																																																												
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V																																																										
B	2014	Beat	Powertrain	Transmission Control Module																																																												
B	2014	Beat	Powertrain	Fuel Injector Control Module																																																												
B	2014	Beat	Chassis	Electronic Brake Control Module																																																												
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
B	2014	Beat	Chassis	Power Steering Control Module																																																											
B	2014	Beat	Chassis	Steering Wheel Angle Sensor Module																																																											
B	2014	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
B	2014	Beat	Body	Instrument Cluster																																																											
B	2014	Beat	Body	Telematics Communication Interface Control Module																																																											
B	2015	Beat	Powertrain	1.0L LEB Engine Control Module																																																											
B	2015	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V																																																										
B	2015	Beat	Powertrain	Transmission Control Module																																																											
B	2015	Beat	Powertrain	Fuel Injector Control Module																																																											
B	2015	Beat	Chassis	Electronic Brake Control Module																																																											
B	2015	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																											
B	2015	Beat	Chassis	Power Steering Control Module																																																											
B	2015	Beat	Chassis	Steering Wheel Angle Sensor Module																																																											
B	2015	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
B	2015	Beat	Body	Instrument Cluster																																																											
B	2015	Beat	Body	Radio																																																											
B	2015	Beat	Body	Telematics Communication Interface Control Module																																																											
B	2015	Beat	Body	Keyless Entry Control Module			V	V																																																							
B	2016	Beat	Powertrain	1.0L LEB Engine Control Module																																																											
B	2016	Beat	Powertrain	1.19L LC5 Engine Control Module	V	V																																																										
B	2016	Beat	Powertrain	Transmission Control Module																																																											
B	2016	Beat	Chassis	Electronic Brake Control Module																																																											
B	2016	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																											
B	2016	Beat	Chassis	Power Steering Control Module																																																											
B	2016	Beat	Chassis	Steering Wheel Angle Sensor Module																																																											
B	2016	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
B	2016	Beat	Body	Instrument Cluster																																																											
B	2016	Beat	Body	Radio																																																											
B	2016	Beat	Body	Telematics Communication Interface Control Module																																																											
B	2016	Beat	Body	HVAC Control Module																																																											
B	2016	Beat	Body	Keyless Entry Control Module			V	V																																																							
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																											
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																											
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																											
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																											
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																											
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																											
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																											
B	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																											
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																											
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																											
B	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																											
B	2016	Cruze	Chassis	Electronic Brake Control Module																																																											
B	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																											
B	2016	Cruze	Chassis	Power Steering Control Module																																																											
B	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
B	2016	Cruze	Body	Body Control Module																																																											
B	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
B	2016	Cruze	Body	Passenger Presence Module																																																											
B	2016	Cruze	Body	Instrument Cluster																																																											
B	2016	Cruze	Body	Radio Controls																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
B	2016	Cruze	Body	HVAC Controls																																																										
B	2016	Cruze	Body	Trailer Interface Control Module																																																										
B	2016	Cruze	Body	Radio Base (IO3 IO7)																																																										
B	2016	Cruze	Body	Radio (IOA)																																																										
B	2016	Cruze	Body	Radio (IOB)																																																										
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																										
B	2016	Cruze	Body	Amplifier																																																										
B	2016	Cruze	Body	Multimedia Player Interface Module																																																										
B	2016	Cruze	Body	Human Machine Interface Control Module																																																										
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																										
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																										
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																										
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																										
B	2016	Cruze	Body	Keyless Entry Control Module																																																										
B	2016	Cruze	Body	Right Side Object Detection Control Module																																																										
B	2016	Cruze	Body	Left Side Object Detection Control Module																																																										
B	2016	Cruze	Body	Parking Assist Control Module					V																																																					
B	2016	Cruze	Body	Frontview Camera Module																																																										
B	2016	Cruze	Body	Steering Column Lock Control Module																																																										
B	2016	Cruze	Body	Long Range Radar Sensor Module																																																										
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																								
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																								
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																								
C	2010	Spark	Powertrain	Transmission Control Module																																																										
C	2010	Spark	Chassis	Electronic Brake Control Module																																																										
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2010	Spark	Chassis	Electric Power Steering Control Module																																																										
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2010	Spark	Body	Passenger Presence Module																																																										
C	2010	Spark	Body	Instrument Cluster																																																										
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																								
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module	V	V																																																								
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module	V	V																																																								
C	2011	Spark	Powertrain	Transmission Control Module																																																										
C	2011	Spark	Chassis	Electronic Brake Control Module																																																										
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2011	Spark	Chassis	Electric Power Steering Control Module																																																										
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2011	Spark	Body	Passenger Presence Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2011	Spark	Body	Instrument Cluster																																																											
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																									
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module	V	V																																																										
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module	V	V																																																										
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module	V	V																																																										
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module	V	V																																																										
C	2012	Spark	Powertrain	Transmission Control Module																																																												
C	2012	Spark	Chassis	Electronic Brake Control Module																																																												
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2012	Spark	Chassis	Electric Power Steering Control Module																																																												
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2012	Spark	Body	Passenger Presence Module																																																												
C	2012	Spark	Body	Instrument Cluster																																																												
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																										
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																										
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module	V	V																																																										
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																												
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module						V																																																						
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module	V	V																																																											
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																													
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module	V																																																											
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																										
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
C	2013	Spark	Powertrain	Fuel Injector Control Module																																																												
C	2013	Spark	Chassis	Electronic Brake Control Module																																																												
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2013	Spark	Chassis	Power Steering Control Module																																																												
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2013	Spark	Body	Body Control Module																																																												
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2013	Spark	Body	Passenger Presence Module																																																												
C	2013	Spark	Body	Instrument Cluster																																																												
C	2013	Spark	Body	Radio																																																											
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module	V	V																																																										
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V					V																																																				
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																										
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																									
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																									
C	2014	Spark	Powertrain	1.0L LFM Transmission Control Module						V																																																			
C	2014	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																								
C	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																								
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																									
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																									
C	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module						V																																																			
C	2014	Spark	Powertrain	1.2L LKY Engine Control Module	V																																																									
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																								
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2014	Spark	Chassis	Electronic Brake Control Module																																																										
C	2014	Spark	Chassis	Electronic Brake Control Module																																																										
C	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2014	Spark	Chassis	Power Steering Control Module																																																										
C	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Spark	Body	Body Control Module																																																									
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark	Body	Passenger Presence Module																																																										
C	2014	Spark	Body	Instrument Cluster																																																										
C	2014	Spark	Body	Radio																																																										
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Spark	Body	Keyless Entry Control Module			V																																																							
C	2014	Spark EV	Powertrain	Engine Control Module																																																										
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2								V																																																	
C	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
C	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
C	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
C	2014	Spark EV	Chassis	Power Steering Control Module																																																										
C	2014	Spark EV	Body	Body Control Module																																																										
C	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark EV	Body	Passenger Presence Module																																																										
C	2014	Spark EV	Body	Instrument Cluster																																																										
C	2014	Spark EV	Body	Radio																																																										
C	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Spark EV	Body	HVAC Control Module																																																										
C	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2014	Spark EV	Body	Coolant Heater Control Module																																																										
C	2014	Spark EV	Body	Keyless Entry Control Module																																																										
C	2014	Spark EV	Body	Battery Charger Control Module																																																										
C	2014	Spark EV	Body	DC Charging Control Module																																																										
C	2014	Spark EV	Body	Battery Energy Control Module									V	V	V	V	V	V																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2015	Spark	Powertrain	0.8L LBF Engine Control Module	V	V																																																									
C	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
C	2015	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V					V																																																				
C	2015	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																									
C	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																											
C	2015	Spark	Powertrain	1.0L LFM Transmission Control Module						V																																																					
C	2015	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																										
C	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
C	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module						V																																																					
C	2015	Spark	Powertrain	1.2L LKY Engine Control Module	V																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2015	Spark	Powertrain	Fuel Injector Control Module																																																											
C	2015	Spark	Chassis	Electronic Brake Control Module																																																											
C	2015	Spark	Chassis	Electronic Brake Control Module																																																											
C	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2015	Spark	Chassis	Power Steering Control Module																																																											
C	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Spark	Body	Body Control Module																																																											
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Spark	Body	Passenger Presence Module																																																											
C	2015	Spark	Body	Instrument Cluster																																																											
C	2015	Spark	Body	Instrument Cluster																																																											
C	2015	Spark	Body	Tire Pressure Indicator Module															V	V																																										
C	2015	Spark	Body	Radio																																																											
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2015	Spark	Body	Keyless Entry Control Module			V																																																								
C	2015	Spark EV	Powertrain	Engine Control Module																																																											
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2								V																																																			
C	2015	Spark EV	Powertrain	Drive Motor Control Module																																																											
C	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
C	2015	Spark EV	Chassis	Electronic Brake Control Module																																																											
C	2015	Spark EV	Chassis	Parking Brake Control Module																																																											
C	2015	Spark EV	Chassis	Power Steering Control Module																																																											
C	2015	Spark EV	Body	Body Control Module																																																											
C	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
C	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Spark EV	Body	Passenger Presence Module																																																											
C	2015	Spark EV	Body	Instrument Cluster																																																											
C	2015	Spark EV	Body	Radio																																																											
C	2015	Spark EV	Body	HVAC Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																									
C	2015	Spark EV	Body	Coolant Heater Control Module																																																										
C	2015	Spark EV	Body	Keyless Entry Control Module																																																										
C	2015	Spark EV	Body	Battery Charger Control Module																																																										
C	2015	Spark EV	Body	DC Charging Control Module																																																										
C	2015	Spark EV	Body	Battery Energy Control Module									V	V	V	V	V																																														
C	2016	Spark	Powertrain	0.8L LBF Engine Control Module	V	V																																																									
C	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V					V																																																				
C	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																										
C	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																									
C	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																									
C	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module						V																																																					
C	2016	Spark	Powertrain	1.2L LKY Engine Control Module	V																																																										
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																										
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	Fuel Injector Control Module																																																											
C	2016	Spark	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2016	Spark	Chassis	Power Steering Control Module																																																											
C	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Spark	Body	Body Control Module																																																											
C	2016	Spark	Body	Body Control Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Instrument Cluster																																																											
C	2016	Spark	Body	Instrument Cluster																																																											
C	2016	Spark	Body	Radio																																																											
C	2016	Spark	Body	Telematics Communication Interface Control Module																																																											
C	2016	Spark	Body	Keyless Entry Control Module			V																																																								
C	2016	Spark EV	Powertrain	Engine Control Module																																																											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2								V																																																		
C	2016	Spark EV	Powertrain	Drive Motor Control Module																																																											
C	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
C	2016	Spark EV	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark EV	Chassis	Parking Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2016	Spark EV	Chassis	Power Steering Control Module																																																											
C	2016	Spark EV	Body	Body Control Module																																																												
C	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																												
C	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Spark EV	Body	Passenger Presence Module																																																												
C	2016	Spark EV	Body	Instrument Cluster																																																												
C	2016	Spark EV	Body	Radio																																																												
C	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																												
C	2016	Spark EV	Body	HVAC Control Module																																																												
C	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																												
C	2016	Spark EV	Body	Coolant Heater Control Module																																																												
C	2016	Spark EV	Body	Keyless Entry Control Module																																																												
C	2016	Spark EV	Body	Frontview Camera Module																																																												
C	2016	Spark EV	Body	Battery Charger Control Module																																																												
C	2016	Spark EV	Body	DC Charging Control Module																																																												
C	2016	Spark EV	Body	Battery Energy Control Module									V	V	V	V	V																																															
D	2010	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																											
D	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
D	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
D	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
D	2010	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																											
D	2010	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																											
D	2010	Spark	Powertrain	Transmission Control Module																																																												
D	2010	Spark	Chassis	Electronic Brake Control Module																																																												
D	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
D	2010	Spark	Chassis	Electric Power Steering Control Module																																																												
D	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2010	Spark	Body	Passenger Presence Module																																																												
D	2010	Spark	Body	Instrument Cluster																																																												
D	2011	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																											
D	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
D	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
D	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
D	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module	V	V																																																										
D	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module	V	V																																																										
D	2011	Spark	Powertrain	Transmission Control Module																																																												
D	2011	Spark	Chassis	Electronic Brake Control Module																																																												
D	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
D	2011	Spark	Chassis	Electric Power Steering Control Module																																																												
D	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2011	Spark	Body	Passenger Presence Module																																																												
D	2011	Spark	Body	Instrument Cluster																																																												
D	2012	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																										
D	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
D	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
D	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
D	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module	V	V																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2012	Spark	Powertrain	1.19L LC5 Engine Control Module	V	V
D	2012	Spark	Powertrain	1.2L L2E Engine Control Module	V	V
D	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module	V	V
D	2012	Spark	Powertrain	Transmission Control Module
D	2012	Spark	Chassis	Electronic Brake Control Module
D	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module
D	2012	Spark	Chassis	Electric Power Steering Control Module
D	2012	Spark	Chassis	Steering Wheel Angle Sensor Module
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module
D	2012	Spark	Body	Passenger Presence Module
D	2012	Spark	Body	Instrument Cluster
D	2013	Spark	Powertrain	1.0L LCP Engine Control Module	V	V
D	2013	Spark	Powertrain	1.0L LCP Transmission Control Module
D	2013	Spark	Powertrain	1.0L LMT Engine Control Module	V	V
D	2013	Spark	Powertrain	1.0L LMT Transmission Control Module
D	2013	Spark	Powertrain	1.19L LC5 Engine Control Module	V	V
D	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission
D	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module						V
D	2013	Spark	Powertrain	1.2L L2E Engine Control Module	V	V
D	2013	Spark	Powertrain	1.2L L2E Transmission Control Module
D	2013	Spark	Powertrain	1.2L LKY Engine Control Module	V
D	2013	Spark	Powertrain	1.2L LMU Engine Control Module	V	V
D	2013	Spark	Powertrain	1.2L LMU Transmission Control Module
D	2013	Spark	Powertrain	Fuel Injector Control Module
D	2013	Spark	Chassis	Electronic Brake Control Module
D	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module
D	2013	Spark	Chassis	Power Steering Control Module
D	2013	Spark	Chassis	Steering Wheel Angle Sensor Module
D	2013	Spark	Body	Body Control Module
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module
D	2013	Spark	Body	Passenger Presence Module
D	2013	Spark	Body	Instrument Cluster
D	2013	Spark	Body	Radio
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 9
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 10
D	2014	Spark	Powertrain	0.8L LBF Engine Control Module	V	V
D	2014	Spark	Powertrain	0.8L LBF Transmission Control Module
D	2014	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V					V
D	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module
D	2014	Spark	Powertrain	1.0L LCP Engine Control Module	V	V
D	2014	Spark	Powertrain	1.0L LCP Transmission Control Module
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission
D	2014	Spark	Powertrain	1.0L LFM Transmission Control Module						V
D	2014	Spark	Powertrain	1.0L LMT Engine Control Module	V	V
D	2014	Spark	Powertrain	1.0L LMT Transmission Control Module
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module	V	V

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
D	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module						V																																																						
D	2014	Spark	Powertrain	1.2L LKY Engine Control Module	V																																																												
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																											
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																													
D	2014	Spark	Powertrain	Fuel Injector Control Module																																																													
D	2014	Spark	Chassis	Electronic Brake Control Module																																																												
D	2014	Spark	Chassis	Electronic Brake Control Module																																																												
D	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
D	2014	Spark	Chassis	Power Steering Control Module																																																												
D	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
D	2014	Spark	Body	Body Control Module																																																												
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2014	Spark	Body	Passenger Presence Module																																																												
D	2014	Spark	Body	Instrument Cluster																																																												
D	2014	Spark	Body	Radio																																																											
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																												
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																												
D	2014	Spark	Body	Keyless Entry Control Module			V																																																									
D	2014	Spark EV	Powertrain	Engine Control Module																																																												
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																												
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2								V																																																				
D	2014	Spark EV	Powertrain	Drive Motor Control Module																																																												
D	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																												
D	2014	Spark EV	Chassis	Electronic Brake Control Module																																																												
D	2014	Spark EV	Chassis	Parking Brake Control Module																																																												
D	2014	Spark EV	Chassis	Power Steering Control Module																																																												
D	2014	Spark EV	Body	Body Control Module																																																												
D	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																												
D	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2014	Spark EV	Body	Passenger Presence Module																																																												
D	2014	Spark EV	Body	Instrument Cluster																																																												
D	2014	Spark EV	Body	Radio																																																											
D	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																												
D	2014	Spark EV	Body	HVAC Control Module																																																												
D	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																												
D	2014	Spark EV	Body	Coolant Heater Control Module																																																												
D	2014	Spark EV	Body	Keyless Entry Control Module																																																												
D	2014	Spark EV	Body	Battery Charger Control Module																																																												
D	2014	Spark EV	Body	DC Charging Control Module																																																												
D	2014	Spark EV	Body	Battery Energy Control Module									V	V	V	V	V	V																																														
D	2015	Spark	Powertrain	0.8L LBF Engine Control Module	V	V																																																											
D	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																												
D	2015	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V					V																																																					
D	2015	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																										
D	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																											
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module						V																																																					
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																									
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																									
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module						V																																																					
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module	V																																																										
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																									
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2015	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2015	Spark	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2015	Spark	Chassis	Power Steering Control Module																																																										
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2015	Spark	Body	Body Control Module																																																									
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark	Body	Passenger Presence Module																																																										
D	2015	Spark	Body	Instrument Cluster																																																										
D	2015	Spark	Body	Instrument Cluster																																																										
D	2015	Spark	Body	Tire Pressure Indicator Module															V	V																																										
D	2015	Spark	Body	Radio																																																										
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2015	Spark	Body	Keyless Entry Control Module			V																																																							
D	2015	Spark EV	Powertrain	Engine Control Module																																																										
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2								V																																																	
D	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
D	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
D	2015	Spark EV	Chassis	Power Steering Control Module																																																										
D	2015	Spark EV	Body	Body Control Module																																																										
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark EV	Body	Passenger Presence Module																																																										
D	2015	Spark EV	Body	Instrument Cluster																																																										
D	2015	Spark EV	Body	Radio																																																										
D	2015	Spark EV	Body	HVAC Control Module																																																										
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
D	2015	Spark EV	Body	Coolant Heater Control Module																																																										
D	2015	Spark EV	Body	Keyless Entry Control Module																																																										
D	2015	Spark EV	Body	Battery Charger Control Module																																																										
D	2015	Spark EV	Body	DC Charging Control Module																																																										
D	2015	Spark EV	Body	Battery Energy Control Module									V	V	V	V	V																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2016	Spark	Powertrain	0.8L LBF Engine Control Module	V	V																																																						
D	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																									
D	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																									
D	2016	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V					V																																																		
D	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																									
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																									
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																									
D	2016	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																								
D	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																									
D	2016	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																							
D	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																									
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																								
D	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																									
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																									
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																									
D	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module						V																																																			
D	2016	Spark	Powertrain	1.2L LKY Engine Control Module	V																																																									
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																								
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																									
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																									
D	2016	Spark	Powertrain	Fuel Injector Control Module																																																									
D	2016	Spark	Chassis	Electronic Brake Control Module																																																									
D	2016	Spark	Chassis	Electronic Brake Control Module																																																									
D	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
D	2016	Spark	Chassis	Power Steering Control Module																																																									
D	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
D	2016	Spark	Body	Body Control Module																																																									
D	2016	Spark	Body	Body Control Module																																																									
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2016	Spark	Body	Instrument Cluster																																																									
D	2016	Spark	Body	Instrument Cluster																																																									
D	2016	Spark	Body	Radio																																																									
D	2016	Spark	Body	Telematics Communication Interface Control Module																																																									
D	2016	Spark	Body	Keyless Entry Control Module			V																																																						
D	2016	Spark EV	Powertrain	Engine Control Module																																																									
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																									
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2								V																																																
D	2016	Spark EV	Powertrain	Drive Motor Control Module																																																									
D	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																									
D	2016	Spark EV	Chassis	Electronic Brake Control Module																																																									
D	2016	Spark EV	Chassis	Parking Brake Control Module																																																									
D	2016	Spark EV	Chassis	Power Steering Control Module																																																									
D	2016	Spark EV	Body	Body Control Module																																																									
D	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																									
D	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2016	Spark EV	Body	Passenger Presence Module																																																									
D	2016	Spark EV	Body	Instrument Cluster																																																									

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2016	Spark EV	Body	Radio																																																										
D	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
D	2016	Spark EV	Body	HVAC Control Module																																																										
D	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
D	2016	Spark EV	Body	Coolant Heater Control Module																																																										
D	2016	Spark EV	Body	Keyless Entry Control Module																																																										
D	2016	Spark EV	Body	Frontview Camera Module																																																										
D	2016	Spark EV	Body	Battery Charger Control Module																																																										
D	2016	Spark EV	Body	DC Charging Control Module																																																										
D	2016	Spark EV	Body	Battery Energy Control Module									V	V	V	V	V																																													
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Automatic Transmission																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Manual Transmission																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Transmission Control Module																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2010	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2010	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2010	Camaro	Chassis	Power Steering Control Module																																																										
F	2010	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2010	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2010	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2010	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2010	Camaro	Body	Passenger Presence Module																																																										
F	2010	Camaro	Body	Instrument Cluster																																																										
F	2010	Camaro	Body	Auxiliary Gage Module																																																										
F	2010	Camaro	Body	Radio																																																										
F	2010	Camaro	Body	Multimedia Player Interface Module																																																										
F	2010	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																										
F	2010	Camaro	Body	Mobile Telephone Control Module																																																										
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2010	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																										
F	2010	Camaro	Body	Front Seat Heating Control Module																																																										
F	2010	Camaro	Body	Folding Top Control Module																V	V																																									
F	2010	Camaro	Body	Parking Assist Control Module																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Automatic Transmission																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Manual Transmission																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																												
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2011	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2011	Camaro	Chassis	Power Steering Control Module																																																												
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2011	Camaro	Body	Passenger Presence Module																																																												
F	2011	Camaro	Body	Instrument Cluster																																																												
F	2011	Camaro	Body	Head-Up Display Module																																																												
F	2011	Camaro	Body	Auxiliary Gage Module																																																												
F	2011	Camaro	Body	Headlamp Control Module																																																												
F	2011	Camaro	Body	Radio																																																											
F	2011	Camaro	Body	Multimedia Player Interface Module																																																												
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																												
F	2011	Camaro	Body	Mobile Telephone Control Module																																																												
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																												
F	2011	Camaro	Body	Front Seat Heating Control Module																																																												
F	2011	Camaro	Body	Folding Top Control Module																	V	V																																									
F	2011	Camaro	Body	Parking Assist Control Module																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module																			V																																									
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																												
F	2012	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2012	Camaro	Chassis	Power Steering Control Module																																																												
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2012	Camaro	Chassis	Suspension Control Module																																																												
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2012	Camaro	Body	Passenger Presence Module																																																												
F	2012	Camaro	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
F	2012	Camaro	Body	Head-Up Display Module																																																											
F	2012	Camaro	Body	Auxiliary Gage Module																																																												
F	2012	Camaro	Body	Headlamp Control Module																																																												
F	2012	Camaro	Body	Radio																																																												
F	2012	Camaro	Body	Multimedia Player Interface Module																																																												
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																												
F	2012	Camaro	Body	Mobile Telephone Control Module																																																												
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																												
F	2012	Camaro	Body	Front Seat Heating Control Module																																																												
F	2012	Camaro	Body	Folding Top Control Module																	V	V																																									
F	2012	Camaro	Body	Parking Assist Control Module																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow																			V																																									
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow																			V																																									
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow																			V																																									
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow																			V																																									
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																												
F	2013	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2013	Camaro	Chassis	Power Steering Control Module																																																												
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2013	Camaro	Chassis	Suspension Control Module																																																												
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2013	Camaro	Body	Passenger Presence Module																																																												
F	2013	Camaro	Body	Instrument Cluster																																																												
F	2013	Camaro	Body	Head-Up Display Module																																																												
F	2013	Camaro	Body	Auxiliary Gage Module																																																												
F	2013	Camaro	Body	Headlamp Control Module																																																												
F	2013	Camaro	Body	Radio																																																											
F	2013	Camaro	Body	Multimedia Player Interface Module																																																												
F	2013	Camaro	Body	Mobile Telephone Control Module																																																												
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
F	2013	Camaro	Body	HVAC Control Module																																																										
F	2013	Camaro	Body	Front Seat Heating Control Module																																																										
F	2013	Camaro	Body	Folding Top Control Module																	V	V																																								
F	2013	Camaro	Body	Parking Assist Control Module																																																										
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																										
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																										
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																										
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																			V																																							
F	2014	Camaro	Powertrain	Transmission Control Module																																																										
F	2014	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2014	Camaro	Chassis	Parking Brake Control Module																																																										
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2014	Camaro	Chassis	Power Steering Control Module																																																										
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2014	Camaro	Chassis	Suspension Control Module																																																										
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2014	Camaro	Body	Passenger Presence Module																																																										
F	2014	Camaro	Body	Instrument Cluster																																																										
F	2014	Camaro	Body	Head-Up Display Module																																																										
F	2014	Camaro	Body	Auxiliary Gage Module																																																										
F	2014	Camaro	Body	Headlamp Control Module																																																										
F	2014	Camaro	Body	Radio																																																										
F	2014	Camaro	Body	Mobile Telephone Control Module																																																										
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2014	Camaro	Body	HVAC Control Module																																																										
F	2014	Camaro	Body	Front Seat Heating Control Module																																																										
F	2014	Camaro	Body	Folding Top Control Module																	V	V																																								
F	2014	Camaro	Body	Parking Assist Control Module																																																										
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module																																																										
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2014	SS	Powertrain	Chassis Control Module																																																										
F	2014	SS	Chassis	Electronic Brake Control Module																																																										
F	2014	SS	Chassis	Parking Brake Control Module																																																										
F	2014	SS	Chassis	Power Steering Control Module																																																										
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2014	SS	Body	Body Control Module																																																										
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2014	SS	Body	Passenger Presence Module																																																										
F	2014	SS	Body	Instrument Cluster																																																										
F	2014	SS	Body	Head-Up Display Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
F	2014	SS	Body	Radio Control																																																								
F	2014	SS	Body	HVAC Control																																																								
F	2014	SS	Body	Headlamp Control Module																																																								
F	2014	SS	Body	Trailer Interface Control Module																																																								
F	2014	SS	Body	Radio																																																								
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9																																																								
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2014	SS	Body	HVAC Control Module																																																								
F	2014	SS	Body	Seat Memory Control Module - Driver																																																								
F	2014	SS	Body	Keyless Entry Control Module																																																								
F	2014	SS	Body	Right Side Object Detection Control Module																																																								
F	2014	SS	Body	Left Side Object Detection Control Module																																																								
F	2014	SS	Body	Parking Assist Control Module																				V																																				
F	2014	SS	Body	Frontview Camera Module																					V																																			
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																								
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																								
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																								
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																								
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																			V			V																																		
F	2015	Camaro	Powertrain	Transmission Control Module																																																								
F	2015	Camaro	Chassis	Electronic Brake Control Module																																																								
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																								
F	2015	Camaro	Chassis	Power Steering Control Module																																																								
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2015	Camaro	Chassis	Suspension Control Module																																																								
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2015	Camaro	Body	Passenger Presence Module																																																								
F	2015	Camaro	Body	Instrument Cluster																																																								
F	2015	Camaro	Body	Head-Up Display Module																																																								
F	2015	Camaro	Body	Auxiliary Gage Module																																																								
F	2015	Camaro	Body	Headlamp Control Module																																																								
F	2015	Camaro	Body	Radio																																																								
F	2015	Camaro	Body	Mobile Telephone Control Module																																																								
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6																																																								
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																								
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2015	Camaro	Body	HVAC Control Module																																																								
F	2015	Camaro	Body	Front Seat Heating Control Module																																																								
F	2015	Camaro	Body	Folding Top Control Module																	V	V																																						
F	2015	Camaro	Body	Parking Assist Control Module																																																								
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2015	SS	Powertrain	Fuel Injector Control Module																																																								
F	2015	SS	Powertrain	Chassis Control Module																			V			V																																		
F	2015	SS	Chassis	Electronic Brake Control Module																																																								
F	2015	SS	Chassis	Parking Brake Control Module																																																								
F	2015	SS	Chassis	Power Steering Control Module																																																								
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2015	SS	Chassis	Suspension Control Module																							V	V																																
F	2015	SS	Body	Body Control Module																																																								
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2015	SS	Body	Passenger Presence Module																																																								
F	2015	SS	Body	Instrument Cluster																																																								
F	2015	SS	Body	Head-Up Display Module																																																								
F	2015	SS	Body	Radio Control																																																								
F	2015	SS	Body	HVAC Control																																																								
F	2015	SS	Body	Headlamp Control Module																																																								
F	2015	SS	Body	Trailer Interface Control Module																																																								
F	2015	SS	Body	Radio																																																								
F	2015	SS	Body	Telematics Communication Interface Control Module																																																								
F	2015	SS	Body	HVAC Control Module																																																								
F	2015	SS	Body	Seat Memory Control Module - Driver																																																								
F	2015	SS	Body	Keyless Entry Control Module																																																								
F	2015	SS	Body	Right Side Object Detection Control Module																																																								
F	2015	SS	Body	Left Side Object Detection Control Module																																																								
F	2015	SS	Body	Parking Assist Control Module																				V																																				
F	2015	SS	Body	Frontview Camera Module																					V																																			
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																								
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																								
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																								
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																								
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																								
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																								
F	2016	Camaro	Powertrain	Transmission Control Module																																																								
F	2016	Camaro	Chassis	Electronic Brake Control Module																																																								
F	2016	Camaro	Chassis	Parking Brake Control Module																																																								
F	2016	Camaro	Chassis	Power Steering Control Module																																																								
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2016	Camaro	Chassis	Suspension Control Module																																																								
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
F	2016	Camaro	Body	Serial Data Gateway Module																																																								
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2016	Camaro	Body	Passenger Presence Module																																																								
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																								
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																								
F	2016	Camaro	Body	Head-Up Display Module																																																								
F	2016	Camaro	Body	Auxiliary Gage Module																																																								
F	2016	Camaro	Body	Radio Controls																																																								
F	2016	Camaro	Body	HVAC Controls																																																								
F	2016	Camaro	Body	Vehicle Performance Data Recorder																																																								
F	2016	Camaro	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
F	2016	Camaro	Body	Amplifier																																																										
F	2016	Camaro	Body	Media Disc Player																																																										
F	2016	Camaro	Body	Human Machine Interface Control Module																																																										
F	2016	Camaro	Body	Navigation Control Module																																																										
F	2016	Camaro	Body	Mobile Telephone Control Module																																																										
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																										
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)																																																										
F	2016	Camaro	Body	Seat Memory Control Module - Driver																																																										
F	2016	Camaro	Body	Folding Top Control Module																	V	V																																								
F	2016	Camaro	Body	Keyless Entry Control Module																																																										
F	2016	Camaro	Body	Right Side Object Detection Control Module																																																										
F	2016	Camaro	Body	Left Side Object Detection Control Module																																																										
F	2016	Camaro	Body	Parking Assist Control Module																																																										
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2016	SS	Powertrain	Fuel Injector Control Module																																																										
F	2016	SS	Chassis	Electronic Brake Control Module																																																										
F	2016	SS	Chassis	Parking Brake Control Module																																																										
F	2016	SS	Chassis	Power Steering Control Module																																																										
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2016	SS	Chassis	Suspension Control Module																																																										
F	2016	SS	Body	Body Control Module																																																										
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2016	SS	Body	Passenger Presence Module																																																										
F	2016	SS	Body	Instrument Cluster																																																										
F	2016	SS	Body	Head-Up Display Module																																																										
F	2016	SS	Body	Radio Control																																																										
F	2016	SS	Body	HVAC Control																																																										
F	2016	SS	Body	Trailer Interface Control Module																																																										
F	2016	SS	Body	Radio																																																										
F	2016	SS	Body	Telematics Communication Interface Control Module																																																										
F	2016	SS	Body	HVAC Control Module																																																										
F	2016	SS	Body	Seat Memory Control Module - Driver																									V																																	
F	2016	SS	Body	Keyless Entry Control Module																																																										
F	2016	SS	Body	Right Side Object Detection Control Module																																																										
F	2016	SS	Body	Left Side Object Detection Control Module																																																										
F	2016	SS	Body	Parking Assist Control Module																				V																																						
F	2016	SS	Body	Frontview Camera Module																																																										
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																										
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
G	2016	Malibu	Powertrain	Fuel Injector Control Module																																																										
G	2016	Malibu	Powertrain	Chassis Control Module																											V																															
G	2016	Malibu	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2016	Malibu	Chassis	Parking Brake Control Module																																																											
G	2016	Malibu	Chassis	Power Steering Control Module																																																												
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																												
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2016	Malibu	Body	Passenger Presence Module																																																												
G	2016	Malibu	Body	Instrument Cluster																																																												
G	2016	Malibu	Body	Headlamp Control Module																																																												
G	2016	Malibu	Body	Radio																																																											
G	2016	Malibu	Body	Digital Radio Receiver Control Module																																																											
G	2016	Malibu	Body	Multimedia Player Interface Module																																																											
G	2016	Malibu	Body	Mobile Telephone Control Module																																																											
G	2016	Malibu	Body	Telematics Communication Interface Control Module																																																											
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																											V																															
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																											V																															
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																											V																															
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																											V																															
G	2016	Malibu	Body	Seat Memory Control Module																																																										
G	2016	Malibu	Body	Front Seat Heating Control Module																																																										
G	2016	Malibu	Body	Rear Seat Heating Control Module																																																										
G	2016	Malibu	Body	Keyless Entry Control Module																																																										
G	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
G	2016	Malibu	Body	Parking Assist Control Module																																																										
G	2016	Malibu	Body	Frontview Camera Module																																																										
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																												V	V																													
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																												V																														
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module																												V																														
H	2010	Sail	Powertrain	Transmission Control Module																													V	V																												
H	2010	Sail	Chassis	Electronic Brake Control Module																																																										
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																											
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																												V	V																												
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																												V																														
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module																												V																														
H	2011	Sail	Powertrain	Transmission Control Module																													V	V																												
H	2011	Sail	Chassis	Electronic Brake Control Module																																																										
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																											
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																												V	V																												
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																												V																														
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																												V	V																												
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																												V																														
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																												V																														
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																												V				V																								
H	2012	Sail	Powertrain	Transmission Control Module																													V	V																												
H	2012	Sail	Chassis	Electronic Brake Control Module																																																										
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																											
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																												V	V																												
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																												V																														
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																												V																														
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																												V				V																										
H	2013	Sail	Powertrain	Transmission Control Module																													V	V																												
H	2013	Sail	Chassis	Electronic Brake Control Module																																																										
H	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																											
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																												V	V																													
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																												V																														
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																												V																														
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																												V				V																										
H	2014	Sail	Powertrain	Transmission Control Module																													V	V																												
H	2014	Sail	Chassis	Electronic Brake Control Module																																																										
H	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																V																										
H	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																	V	V																								
H	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																	V	V																								
H	2015	Sail	Chassis	Electronic Brake Control Module																																																										
H	2015	Sail	Chassis	Power Steering Control Module																																																										
H	2015	Sail	Body	Body Control Module																																			V																							
H	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Sail	Body	Radio/HVAC Control																																																										
H	2015	Sail	Body	HVAC Control Module																											V																															
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																	V	V																								
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																	V	V																								
H	2016	Sail	Powertrain	1.5L L2B Transmission Control Module						V																																																				
H	2016	Sail	Chassis	Electronic Brake Control Module																																																										
H	2016	Sail	Chassis	Power Steering Control Module																																																										
H	2016	Sail	Body	Body Control Module																																			V																							
H	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Sail	Body	Radio/HVAC Control																																																										
H	2016	Sail	Body	Radio																																																										
H	2016	Sail	Body	HVAC Control Module																											V																															
J	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																			V	V	V	V	V																			
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																			V	V	V	V	V																			
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																							V	V																		
J	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																							V	V																		
J	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																							V	V																		
J	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V	V																		
J	2004	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
J	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																									V	V																
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
J	2004	Optra	Body	Remote Function Actuation																																																										
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel																																											V	V														
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel Transmission Control Module																																																										
J	2004	Cavalier	Chassis	Anti-lock Brake System																																																										
J	2004	Cavalier	Body	Body Control Module																																													V	V												
J	2004	Cavalier	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2004	Cavalier	Body	Instrument Panel Cluster																																															V									
J	2004	Cavalier	Body	Radio																																																								
J	2004	Cavalier	Body	Supplemental Inflatable Restraint																																																								
J	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																			V	V	V	V	V																	
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V										V	V							
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																							V	V																
J	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																							V	V																
J	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																							V	V																
J	2005	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																								
J	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																									V	V														
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																							
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																							
J	2005	Optra	Body	Remote Function Actuation																																																							
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																							
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																							
J	2005	Cavalier	Chassis	Anti-lock Brake System																																																							
J	2005	Cavalier	Body	Body Control Module																																												V	V										
J	2005	Cavalier	Body	Digital Radio Receiver																																																							
J	2005	Cavalier	Body	Instrument Panel Cluster																																													V									
J	2005	Cavalier	Body	Radio																																																							
J	2005	Cavalier	Body	Supplemental Inflatable Restraint																																																							
J	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																						V									V	V							
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V									V	V							
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																							V	V																
J	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																							V	V																
J	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																							V	V																
J	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																							V	V																
J	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V	V																
J	2006	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																							
J	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																									V	V														
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																							
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																							
J	2006	ALL	Body	Remote Function Actuation																																																							
J	2006	ALL	Body	Supplemental Inflatable Restraint																																																		V						
J	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																						V									V	V							
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V									V	V							
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																							V	V																
J	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																							V																	
J	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																							V																	
J	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																								V												V				
J	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																			V	V	V	V	V
J	2007	ALL	Powertrain	4 Speed Automatic																																																								
J	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																									V	V														
J	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																							
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																							
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																							
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																							
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																							
J	2007	ALL	Chassis	Tire Pressure Monitor																																																							
J	2007	ALL	Body	Remote Function Actuation																																																							
J	2007	ALL	Body	Supplemental Inflatable Restraint																																																							

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V									V	V							
J	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																							V									V	V							
J	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																							V									V	V							
J	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																								V																
J	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																								V																
J	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																			V	V	V	V	V
J	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																									V											V					
J	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																																																		V	V	V	V	V
J	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																								
J	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																										V	V														
J	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																								
J	2008	ALL	Chassis	Tire Pressure Monitor																																																								
J	2008	ALL	Body	Remote Function Actuation																																																								
J	2008	ALL	Body	Supplemental Inflatable Restraint																																																		V						
J	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V									V	V							
J	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																							V									V	V							
J	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																							V									V	V							
J	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																								V																
J	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																								V																
J	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																			V	V	V	V	V
J	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																									V											V					
J	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																								
J	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																										V	V														
J	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																								
J	2009	ALL	Chassis	Tire Pressure Monitor																																																								
J	2009	ALL	Body	Remote Function Actuation																																																								
J	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																								
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																								
J	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																								
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																								
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																								
J	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																								
J	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																								
J	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																								
J	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																								
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																								
J	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																								
J	2010	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2010	Cruze	Body	Body Control Module																																																								
J	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2010	Cruze	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2010	Cruze	Body	Instrument Cluster																																																										
J	2010	Cruze	Body	Trailer Interface Control Module																																																										
J	2010	Cruze	Body	Radio																																																										
J	2010	Cruze	Body	Multimedia Player Interface Module																																																										
J	2010	Cruze	Body	Mobile Telephone Control Module																																																										
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
J	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
J	2010	Cruze	Body	Keyless Entry Control Module																																																										
J	2010	Cruze	Body	Parking Assist Control Module																																																										
J	2010	Cruze	Body	Steering Column Lock Control Module																																																										
J	2010	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																								V								V	V							
J	2010	Other	Powertrain	(6)1.6L L4 LXT Engine Control Module																																								V								V	V							
J	2010	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																									V															
J	2010	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																					V	V	V	V	V
J	2010	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																									V															
J	2010	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2010	Other	Powertrain	MFA Transmission Control Module 4 Speed																																											V	V														
J	2010	Other	Powertrain	Transmission Control Module 5 Speed																																																										
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2010	Other	Chassis	Tire Pressure Monitor																																																										
J	2010	Other	Body	Remote Function Actuation																																																										
J	2010	Other	Body	Supplemental Inflatable Restraint																																																										
J	2010	Other	Body	Supplemental Inflatable Restraint																																																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																										
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																										
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																										
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																										
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																										
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																										
J	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																										
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																										
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																										
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																										
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																										
J	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
J	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																										
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2011	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2011	Cruze	Body	Body Control Module																																																										
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2011	Cruze	Body	Passenger Presence Module																																																										
J	2011	Cruze	Body	Instrument Cluster																																																										
J	2011	Cruze	Body	Trailer Interface Control Module																																																										
J	2011	Cruze	Body	Radio																																																										
J	2011	Cruze	Body	Multimedia Player Interface Module																																																										
J	2011	Cruze	Body	Mobile Telephone Control Module																																																										
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
J	2011	Cruze	Body	Keyless Entry Control Module																																																										
J	2011	Cruze	Body	Parking Assist Control Module																																																										
J	2011	Cruze	Body	Steering Column Lock Control Module																																																										
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																										
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2011	Other	Powertrain	Transmission Control Module 5 Speed																																																										
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2011	Other	Chassis	Tire Pressure Monitor																																																										
J	2011	Other	Body	Remote Function Actuation																																																										
J	2011	Other	Body	Supplemental Inflatable Restraint																																																										
J	2011	Other	Body	Supplemental Inflatable Restraint																																																										
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																										
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2012	Aveo	Powertrain	Fuel Pump Control Module																																																													
J	2012	Aveo	Powertrain	Fuel Injector Control Module																																																												
J	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Aveo	Chassis	Electric Power Steering Control Module																																																												
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Aveo	Body	Body Control Module Hatchback																																																												
J	2012	Aveo	Body	Body Control Module Sedan																																																												
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2012	Aveo	Body	Passenger Presence Module																																																												
J	2012	Aveo	Body	Instrument Cluster																																																												
J	2012	Aveo	Body	Radio																																																											
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																												
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
J	2012	Aveo	Body	Front Seat Heating Control Module																																																												
J	2012	Aveo	Body	Parking Assist Control Module																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																												
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2012	Cobalt	Chassis	Electronic Brake Control Module																																																												
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																												
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Cobalt	Body	Body Control Module																																																												
J	2012	Cobalt	Body	Passenger Presence Module																																																												
J	2012	Cobalt	Body	Instrument Cluster																																																												
J	2012	Cobalt	Body	Radio																																																											
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																												
J	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																												
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
J	2012	Cobalt	Body	Front Seat Heating Control Module																																																												
J	2012	Cobalt	Body	Parking Assist Control Module																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																												
J	2012	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Cruze	Body	Body Control Module Hatchback																																																												
J	2012	Cruze	Body	Body Control Module Sedan																																																												
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2012	Cruze	Body	Passenger Presence Module																																																												
J	2012	Cruze	Body	Instrument Cluster																																																												
J	2012	Cruze	Body	Trailer Interface Control Module																																																												
J	2012	Cruze	Body	Radio																																																											
J	2012	Cruze	Body	Multimedia Player Interface Module																																																											
J	2012	Cruze	Body	Mobile Telephone Control Module																																																											
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
J	2012	Cruze	Body	Keyless Entry Control Module																																																										
J	2012	Cruze	Body	Parking Assist Control Module																																																										
J	2012	Cruze	Body	Steering Column Lock Control Module																																																										
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																										
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																										
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																										
J	2012	Sonic (First Gen)	Body	Remote Function Actuation																																																										
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																										
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																										
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module																																																										
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																										
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module Chassis Expansion CAN BUS																																																										
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module High Speed CAN Bus																																																										
J	2012	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																										
J	2012	Sonic (Second Gen)	Body	Body Control Module Sedan																																																										
J	2012	Sonic (Second Gen)	Body	Passenger Presence Module																																																										
J	2012	Sonic (Second Gen)	Body	Instrument Cluster																																																										
J	2012	Sonic (Second Gen)	Body	Radio																																																										
J	2012	Sonic (Second Gen)	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																										
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																										
J	2012	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																										
J	2012	Sonic (Second Gen)	Body	Parking Assist Control Module																																																										
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2013	Aveo	Powertrain	Fuel Pump Control Module																																																										
J	2013	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2013	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Aveo	Chassis	Electric Power Steering Control Module																																																										
J	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Aveo	Body	Body Control Module Hatchback																																																										
J	2013	Aveo	Body	Body Control Module Sedan																																																										
J	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Aveo	Body	Passenger Presence Module																																																										
J	2013	Aveo	Body	Instrument Cluster																																																										
J	2013	Aveo	Body	Radio																																																										
J	2013	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Aveo	Body	Front Seat Heating Control Module																																																										
J	2013	Aveo	Body	Parking Assist Control Module																																																										
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2013	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Cobalt	Body	Body Control Module																																																										
J	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Cobalt	Body	Instrument Cluster																																																										
J	2013	Cobalt	Body	Radio																																																										
J	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																										
J	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2013	Cobalt	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																										V																																
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																										V																																
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																										V																																
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2013	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Cruze	Body	Body Control Module Hatchback																																																										
J	2013	Cruze	Body	Body Control Module Sedan																																																										
J	2013	Cruze	Body	Body Control Module Station Wagon																																																										
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Cruze	Body	Passenger Presence Module																																																										
J	2013	Cruze	Body	Instrument Cluster																																																										
J	2013	Cruze	Body	Trailer Interface Control Module																																																										
J	2013	Cruze	Body	Radio																																																										
J	2013	Cruze	Body	Digital Radio Receiver Control Module																																																										
J	2013	Cruze	Body	Multimedia Player Interface Module																																																										
J	2013	Cruze	Body	Mobile Telephone Control Module																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
J	2013	Cruze	Body	Front Seat Heating Control Module																																																										
J	2013	Cruze	Body	Keyless Entry Control Module																																																										
J	2013	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Body	Steering Column Lock Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V									V	V									
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																							V									V	V									
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																									V																	
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																					V	V	V	V	V
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																										V	V															
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																								
J	2013	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																								
J	2013	Sonic (First Gen)	Body	Remote Function Actuation																																																								
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																								
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																								
J	2013	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2013	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																								
J	2013	Sonic (Second Gen)	Body	Body Control Module Sedan																																																								
J	2013	Sonic (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2013	Sonic (Second Gen)	Body	Passenger Presence Module																																																								
J	2013	Sonic (Second Gen)	Body	Instrument Cluster																																																								
J	2013	Sonic (Second Gen)	Body	Radio																																																								
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																								
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																											
J	2013	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																												
J	2013	Sonic (Second Gen)	Body	Parking Assist Control Module																																																												
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2013	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
J	2013	Spin	Powertrain	1.8L LMD Transmission Control Module																																																												
J	2013	Spin	Chassis	Electronic Brake Control Module																																																												
J	2013	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2013	Spin	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2013	Spin	Body	Body Control Module																																																												
J	2013	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2013	Spin	Body	Instrument Cluster																																																												
J	2013	Spin	Body	Radio																																																												
J	2013	Spin	Body	HVAC Control Module Heater Only (C41)																																																												
J	2013	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2013	Spin	Body	HVAC Control Module Single Zone (C60)																																																												
J	2013	Spin	Body	Parking Assist Control Module																																																												
J	2014	Aveo	Powertrain	1.2L LMU Engine Control Module	V	V					V																																																						
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
J	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																												
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																												
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																											
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
J	2014	Aveo	Powertrain	Chassis Control Module																																																												
J	2014	Aveo	Powertrain	Fuel Injector Control Module																																																												
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2014	Aveo	Chassis	Power Steering Control Module																																																												
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Aveo	Body	Body Control Module Hatchback																																																												
J	2014	Aveo	Body	Body Control Module Sedan																																																												
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Aveo	Body	Instrument Cluster																																																												
J	2014	Aveo	Body	Radio																																																											
J	2014	Aveo	Body	Telematics Communication Interface Control Module																																																											
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
J	2014	Aveo	Body	Front Seat Heating Control Module																																																											
J	2014	Aveo	Body	Keyless Entry Control Module			V																																																								
J	2014	Aveo	Body	Parking Assist Control Module																																																											
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2014	Cobalt	Chassis	Electronic Brake Control Module																																																											
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2014	Cobalt	Body	Body Control Module																																																											
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2014	Cobalt	Body	Instrument Cluster																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2014	Cobalt	Body	Radio																																																										
J	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2014	Cobalt	Body	Parking Assist Control Module																																																										
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																										V																																
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																										V																																
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																										V																																
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																										V																																		
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																										V																																		
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																												
J	2014	Cruze	Powertrain	Fuel Injector Control Module																																																												
J	2014	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2014	Cruze	Chassis	Power Steering Control Module																																																												
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Cruze	Body	Body Control Module Hatchback																																																												
J	2014	Cruze	Body	Body Control Module Sedan																																																												
J	2014	Cruze	Body	Body Control Module Station Wagon																																																												
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Cruze	Body	Passenger Presence Module																																																												
J	2014	Cruze	Body	Instrument Cluster																																																												
J	2014	Cruze	Body	Trailer Interface Control Module																																																												
J	2014	Cruze	Body	Radio																																																											
J	2014	Cruze	Body	Digital Radio Receiver Control Module																																																												
J	2014	Cruze	Body	Multimedia Player Interface Module																																																												
J	2014	Cruze	Body	Mobile Telephone Control Module																																																												
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																												
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																												
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																												
J	2014	Cruze	Body	Front Seat Heating Control Module																																																												
J	2014	Cruze	Body	Keyless Entry Control Module																																																												
J	2014	Cruze	Body	Right Side Object Detection Control Module																																																												
J	2014	Cruze	Body	Left Side Object Detection Control Module																																																												
J	2014	Cruze	Body	Parking Assist Control Module																																																												
J	2014	Cruze	Body	Steering Column Lock Control Module																																																												
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module																																																												
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2014	Sonic	Powertrain	1.4L LDD Chassis Control Module																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Chassis Control Module																																																										
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Chassis Control Module																																																										
J	2014	Sonic	Powertrain	Fuel Injector Control Module																																																										
J	2014	Sonic	Chassis	Electronic Brake Control Module																																																										
J	2014	Sonic	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Sonic	Chassis	Power Steering Control Module																																																										
J	2014	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Sonic	Body	Body Control Module Hatchback																																																										
J	2014	Sonic	Body	Body Control Module Sedan																																																										
J	2014	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Sonic	Body	Passenger Presence Module																																																										
J	2014	Sonic	Body	Instrument Cluster																																																										
J	2014	Sonic	Body	Radio																																																										
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Sonic	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Sonic	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Sonic	Body	Front Seat Heating Control Module																																																										
J	2014	Sonic	Body	Parking Assist Control Module																																																										
J	2014	Sonic	Body	Frontview Camera Module																					V																																					
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.5L L2B Transmission Control Module																																																										
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2014	Spin	Chassis	Electronic Brake Control Module																																																										
J	2014	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Spin	Body	Body Control Module																																																										
J	2014	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Spin	Body	Instrument Cluster																																																										
J	2014	Spin	Body	Radio																																																										
J	2014	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Spin	Body	Parking Assist Control Module																																																										
J	2015	Aveo	Powertrain	1.2L LMU Engine Control Module	V	V					V																																																			
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
J	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
J	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																											
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
J	2015	Aveo	Powertrain	Chassis Control Module																																																													
J	2015	Aveo	Powertrain	Fuel Injector Control Module																																																												
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2015	Aveo	Chassis	Power Steering Control Module																																																												
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2015	Aveo	Body	Body Control Module Hatchback																																																												
J	2015	Aveo	Body	Body Control Module Sedan																																																												
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2015	Aveo	Body	Instrument Cluster																																																												
J	2015	Aveo	Body	Radio																																																											
J	2015	Aveo	Body	Telematics Communication Interface Control Module																																																												
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
J	2015	Aveo	Body	Front Seat Heating Control Module																																																												
J	2015	Aveo	Body	Keyless Entry Control Module			V																																																								
J	2015	Aveo	Body	Parking Assist Control Module																																																												
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
J	2015	Cobalt	Chassis	Electronic Brake Control Module																																																												
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2015	Cobalt	Body	Body Control Module																																																												
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2015	Cobalt	Body	Instrument Cluster																																																												
J	2015	Cobalt	Body	Radio																																																											
J	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																												
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2015	Cobalt	Body	Parking Assist Control Module																																																										
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																										V																																
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																										V																																
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																										V																																
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																										V																																
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																										V																																
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																										
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																										V																																
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																										
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																										
J	2015	Cruze	Powertrain	Fuel Injector Control Module																																																										
J	2015	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2015	Cruze	Chassis	Power Steering Control Module																																																										
J	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Cruze	Body	Body Control Module Hatchback																																																										
J	2015	Cruze	Body	Body Control Module Sedan																																																										
J	2015	Cruze	Body	Body Control Module Station Wagon																																																										
J	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Cruze	Body	Passenger Presence Module																																																										
J	2015	Cruze	Body	Instrument Cluster																																																										
J	2015	Cruze	Body	Trailer Interface Control Module																																																										
J	2015	Cruze	Body	Radio																																																										
J	2015	Cruze	Body	Digital Radio Receiver Control Module																																																										
J	2015	Cruze	Body	Multimedia Player Interface Module																																																										
J	2015	Cruze	Body	Mobile Telephone Control Module																																																										
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
J	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
J	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
J	2015	Cruze	Body	Front Seat Heating Control Module																																																										
J	2015	Cruze	Body	Keyless Entry Control Module																																																										
J	2015	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2015	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2015	Cruze	Body	Parking Assist Control Module																				V																																						
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2015	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	1.6L LED Transmission Control Module																																																										
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2015	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2015	Sonic	Powertrain	Chassis Control Module																																																										
J	2015	Sonic	Powertrain	Fuel Injector Control Module																																																										
J	2015	Sonic	Chassis	Electronic Brake Control Module																																																										
J	2015	Sonic	Chassis	Power Steering Control Module																																																										
J	2015	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Sonic	Body	Body Control Module Hatchback																																																										
J	2015	Sonic	Body	Body Control Module Sedan																																																										
J	2015	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Sonic	Body	Passenger Presence Module																																																										
J	2015	Sonic	Body	Instrument Cluster																																																										
J	2015	Sonic	Body	Radio																																																										
J	2015	Sonic	Body	Telematics Communication Interface Control Module																																																										
J	2015	Sonic	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Sonic	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Sonic	Body	Front Seat Heating Control Module																																																										
J	2015	Sonic	Body	Parking Assist Control Module																																																										
J	2015	Sonic	Body	Frontview Camera Module																					V																																					
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.5L L2B Transmission Control Module																																																										
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
J	2015	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2015	Spin	Chassis	Electronic Brake Control Module																																																										
J	2015	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Spin	Body	Body Control Module																																																										
J	2015	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Spin	Body	Instrument Cluster																																																										
J	2015	Spin	Body	Radio																																																										
J	2015	Spin	Body	Telematics Communication Interface Control Module																																																										
J	2015	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Spin	Body	Front Seat Heating Control Module																																																										
J	2015	Spin	Body	Parking Assist Control Module																																																										
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
J	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
J	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
J	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2016	Aveo	Powertrain	Chassis Control Module																																																										
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2016	Aveo	Chassis	Power Steering Control Module																																																												
J	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Aveo	Body	Body Control Module Hatchback																																																												
J	2016	Aveo	Body	Body Control Module Sedan																																																												
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Aveo	Body	Instrument Cluster																																																												
J	2016	Aveo	Body	Radio																																																												
J	2016	Aveo	Body	Telematics Communication Interface Control Module																																																												
J	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
J	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
J	2016	Aveo	Body	Front Seat Heating Control Module																																																												
J	2016	Aveo	Body	Parking Assist Control Module																																																												
J	2016	Aveo	Body	Keyless Entry Control Module			V																																																									
J	2016	Aveo	Body	Frontview Camera Module																																																												
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
J	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
J	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
J	2016	Cobalt	Chassis	Electronic Brake Control Module																																																												
J	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Cobalt	Body	Body Control Module																																																												
J	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Cobalt	Body	Instrument Cluster																																																												
J	2016	Cobalt	Body	Radio Other																																																												
J	2016	Cobalt	Body	Radio (IOB)																																																												
J	2016	Cobalt	Body	Radio (UF7)																																																												
J	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												
J	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
J	2016	Cobalt	Body	Front Seat Heating Control Module																																																												
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																												
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
J	2016	Cruze	Powertrain	Fuel Injector Control Module																																																												
J	2016	Cruze	Powertrain	Chassis Control Module																																																												
J	2016	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2016	Cruze	Chassis	Power Steering Control Module																																																												
J	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Cruze	Body	Body Control Module Hatchback																																																												
J	2016	Cruze	Body	Body Control Module Sedan																																																												
J	2016	Cruze	Body	Body Control Module Station Wagon																																																												
J	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Cruze	Body	Passenger Presence Module																																																												
J	2016	Cruze	Body	Instrument Cluster																																																												
J	2016	Cruze	Body	Trailer Interface Control Module																																																												
J	2016	Cruze	Body	Radio Other																																																											
J	2016	Cruze	Body	Radio (UF7)																																																											
J	2016	Cruze	Body	Multimedia Player Interface Module																																																											
J	2016	Cruze	Body	Mobile Telephone Control Module																																																											
J	2016	Cruze	Body	Telematics Communication Interface Control Module																																																											
J	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
J	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																											
J	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																											
J	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																											
J	2016	Cruze	Body	Front Seat Heating Control Module																																																											
J	2016	Cruze	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2016	Cruze	Body	Right Side Object Detection Control Module																																																											
J	2016	Cruze	Body	Left Side Object Detection Control Module																																																												
J	2016	Cruze	Body	Parking Assist Control Module																																																												
J	2016	Cruze	Body	Steering Column Lock Control Module																																																												
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																												
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module																																																												
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2016	Sonic	Powertrain	Chassis Control Module																																																												
J	2016	Sonic	Powertrain	Fuel Injector Control Module																																																												
J	2016	Sonic	Chassis	Electronic Brake Control Module																																																												
J	2016	Sonic	Chassis	Power Steering Control Module																																																												
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Sonic	Body	Body Control Module Hatchback																																																												
J	2016	Sonic	Body	Body Control Module Sedan																																																												
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Sonic	Body	Passenger Presence Module																																																												
J	2016	Sonic	Body	Instrument Cluster																																																												
J	2016	Sonic	Body	Radio Other																																																											
J	2016	Sonic	Body	Radio (UF7)																																																											
J	2016	Sonic	Body	Radio (UH7)																																																											
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7																																																											
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Sonic	Body	Front Seat Heating Control Module																																																												
J	2016	Sonic	Body	Parking Assist Control Module																																																												
J	2016	Sonic	Body	Frontview Camera Module																																																												
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module																																																												
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module																																																												
J	2016	Spin	Chassis	Electronic Brake Control Module																																																												
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Spin	Body	Body Control Module																																																												
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Spin	Body	Instrument Cluster																																																												
J	2016	Spin	Body	Radio																																																												
J	2016	Spin	Body	Telematics Communication Interface Control Module																																																												
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)																																																												
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)																																																												
J	2016	Spin	Body	Front Seat Heating Control Module																																																												
J	2016	Spin	Body	Parking Assist Control Module																																																												
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V									V	V									
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																						V									V	V									
K	2006	ALL	Powertrain	Transmission Control Module																																																												
K	2006	ALL	Chassis	Electronic Brake Control Module																																																												
K	2006	ALL	Body	Remote Function Actuation																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V									V	V									
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																						V									V	V									
K	2007	ALL	Powertrain	Transmission Control Module																																																												
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module																																																												
K	2007	ALL	Chassis	Teves Electronic Brake Control Module																																																												
K	2007	ALL	Body	Remote Function Actuation																																																												
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V									V	V									
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																						V									V	V									
K	2008	ALL	Powertrain	Transmission Control Module																																																												
K	2008	ALL	Chassis	Electronic Brake Control Module																																																												
K	2008	ALL	Body	Remote Function Actuation																																																												
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V									V	V									
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																						V									V	V									
K	2009	ALL	Powertrain	Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2009	ALL	Chassis	Electronic Brake Control Module																																																											
K	2009	ALL	Body	Remote Function Actuation																																																												
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2010	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V								V	V										
K	2010	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																						V								V	V										
K	2010	ALL	Powertrain	Transmission Control Module																																																											
K	2010	ALL	Chassis	Electronic Brake Control Module																																																											
K	2010	ALL	Body	Remote Function Actuation																																																											
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2011	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V								V	V										
K	2011	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																						V								V	V										
K	2011	ALL	Powertrain	Transmission Control Module																																																											
K	2011	ALL	Chassis	Electronic Brake Control Module																																																											
K	2011	ALL	Body	Remote Function Actuation																																																											
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2012	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V								V	V										
K	2012	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																						V								V	V										
K	2012	ALL	Powertrain	Transmission Control Module																																																											
K	2012	ALL	Chassis	Electronic Brake Control Module																																																											
K	2012	ALL	Body	Remote Function Actuation																																																											
K	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2013	Onix	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V								V	V										
K	2013	Onix	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																						V								V	V										
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																											
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																											
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																											
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																											
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																											
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																											
K	2013	Onix	Powertrain	Transmission Control Module																																																												
K	2013	Onix	Powertrain	Transmission Control Module																																																												
K	2013	Onix	Chassis	Electronic Brake Control Module																																																											
K	2013	Onix	Chassis	Electronic Brake Control Module																																																											
K	2013	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																											
K	2013	Onix	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2013	Onix	Body	Body Control Module																																																											
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2013	Onix	Body	Instrument Cluster																																																											
K	2013	Onix	Body	Radio																																																											
K	2013	Onix	Body	Parking Assist Control Module																																																											
K	2013	Onix	Body	Remote Function Actuation																																																											
K	2013	Prisma	Powertrain	Engine Control Module																																																											
K	2013	Prisma	Powertrain	Transmission Control Module																																																											
K	2013	Prisma	Chassis	Electronic Brake Control Module																																																											
K	2013	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																											
K	2013	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2013	Prisma	Body	Body Control Module																																																											
K	2013	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2013	Prisma	Body	Instrument Cluster																																																											
K	2013	Prisma	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2013	Prisma	Body	Parking Assist Control Module																																																											
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																												
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																												
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																												
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																												
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																												
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																												
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																												
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module																																																												
K	2014	Onix	Chassis	Electronic Brake Control Module																																																												
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2014	Onix	Body	Body Control Module																																																												
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Onix	Body	Instrument Cluster																																																												
K	2014	Onix	Body	Radio																																																												
K	2014	Onix	Body	Parking Assist Control Module																																																												
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																												
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																												
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module																																																												
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																												
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																												
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																												
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																												
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																												
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																												
K	2014	Prisma	Chassis	Electronic Brake Control Module																																																												
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2014	Prisma	Body	Body Control Module																																																												
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Prisma	Body	Instrument Cluster																																																												
K	2014	Prisma	Body	Radio																																																												
K	2014	Prisma	Body	Parking Assist Control Module																																																												
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																												
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																												
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																												
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																												
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																												
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																												
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																												
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module																																																												
K	2015	Onix	Chassis	Electronic Brake Control Module																																																												
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Onix	Body	Body Control Module																																																												
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Onix	Body	Instrument Cluster																																																												
K	2015	Onix	Body	Radio																																																												
K	2015	Onix	Body	Parking Assist Control Module																																																												
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																												
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2015	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2015	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Prisma	Body	Body Control Module																																																										
K	2015	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Prisma	Body	Instrument Cluster																																																										
K	2015	Prisma	Body	Radio																																																										
K	2015	Prisma	Body	Parking Assist Control Module																																																										
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2016	Onix	Chassis	Electronic Brake Control Module																																																										
K	2016	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Onix	Body	Body Control Module																																																										
K	2016	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Onix	Body	Instrument Cluster																																																										
K	2016	Onix	Body	Radio																																																										
K	2016	Onix	Body	Parking Assist Control Module																																																										
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2016	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2016	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Prisma	Body	Body Control Module																																																										
K	2016	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Prisma	Body	Instrument Cluster																																																										
K	2016	Prisma	Body	Radio																																																										
K	2016	Prisma	Body	HVAC Control Module																																																										
K	2016	Prisma	Body	Front Seat Heating Control Module																																																										
K	2016	Prisma	Body	Parking Assist Control Module																																																										
L	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
L	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2004	ALL	Powertrain	Transmission Control Module																																																										
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																										
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																										
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2004	ALL	Body	ISU																																																										
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2005	ALL	Powertrain	Transmission Control Module																																																										
L	2005	ALL	Chassis	Anti-lock Brake System																																																										
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2005	ALL	Body	ISU																																																										
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																										
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																										
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2006	ALL	Body	ISU																																																										
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																										
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																										
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector																																																										
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module																																																										
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Body	ISU																																																										
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																										
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																										
L	2008	ALL	Chassis	Electronic Brake Control Module																																																										
L	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2008	ALL	Body	ISU																																																										
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																										
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																										
L	2009	ALL	Chassis	Electronic Brake Control Module																																																										
L	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2009	ALL	Body	ISU																																																										
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																										
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																										
L	2010	ALL	Chassis	Electronic Brake Control Module																																																										
L	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2010	ALL	Body	ISU																																																										
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																							V	V	V	V
L	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																										
L	2011	ALL	Chassis	Electronic Brake Control Module																																																										
L	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2011	ALL	Body	ISU																																																										
M	2004	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																			V	V	V	V	V																		
M	2004	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																			V	V	V	V	V																		
M	2004	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																				V	V																			
M	2004	ALL	Chassis	Anti-lock Brake System																																																									
M	2004	ALL	Body	Remote Function Actuation																																																									
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
M	2005	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V	V																		
M	2005	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																V								
M	2005	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																															V								
M	2005	ALL	Chassis	Anti-lock Brake System																																																									
M	2005	ALL	Body	Remote Function Actuation																																																									
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
M	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V	V																		
M	2006	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																															V								
M	2006	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																															V								
M	2006	ALL	Chassis	Anti-lock Brake System																																																									
M	2006	ALL	Body	Remote Function Actuation																																																									
M	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
M	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V	V																		
M	2007	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																															V								
M	2007	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																															V								
M	2007	ALL	Chassis	Anti-lock Brake System																																																									
M	2007	ALL	Body	Remote Function Actuation																																																									
M	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
M	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V	V																		
M	2008	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																															V								
M	2008	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																															V								
M	2008	ALL	Chassis	Anti-lock Brake System																																																									
M	2008	ALL	Body	Remote Function Actuation																																																									
M	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
M	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																						V	V																		
M	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																															V								
M	2009	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																															V								
M	2009	ALL	Chassis	Anti-lock Brake System																																																									
M	2009	ALL	Body	Remote Function Actuation																																																									
M	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
M	2010	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																								
M	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
M	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
M	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
M	2010	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																								
M	2010	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																								
M	2010	Spark	Powertrain	Transmission Control Module																																																										
M	2010	Spark	Chassis	Electronic Brake Control Module																																																										
M	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2010	Spark	Chassis	Electric Power Steering Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
M	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2010	Spark	Body	Passenger Presence Module																																																										
M	2010	Spark	Body	Instrument Cluster																																																										
M	2011	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																									V	
M	2011	Caprice	Powertrain	Transmission Control Module																																																										
M	2011	Caprice	Powertrain	Fuel Pump Control Module																																																										
M	2011	Caprice	Chassis	Electronic Brake Control Module																																																										
M	2011	Caprice	Body	Body Control Module																																																										
M	2011	Caprice	Body	HVAC Control Module																																																										
M	2011	Caprice	Body	Instrument Panel Cluster																																																										
M	2011	Caprice	Body	Passenger Presence System																																																										
M	2011	Caprice	Body	Radio																																																										
M	2011	Caprice	Body	Remote Control Door Lock Receiver																																																										
M	2011	Caprice	Body	Supplemental Inflatable Restraint																																																										
M	2011	Caprice	Body	Theft Deterrent Module																																																										
M	2011	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																								
M	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
M	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
M	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
M	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module	V	V																																																								
M	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module	V	V																																																								
M	2011	Spark	Powertrain	Transmission Control Module																																																										
M	2011	Spark	Chassis	Electronic Brake Control Module																																																										
M	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2011	Spark	Chassis	Electric Power Steering Control Module																																																										
M	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2011	Spark	Body	Passenger Presence Module																																																										
M	2011	Spark	Body	Instrument Cluster																																																										
M	2012	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
M	2012	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																									V	
M	2012	Caprice	Powertrain	Transmission Control Module																																																										
M	2012	Caprice	Powertrain	Fuel Pump Control Module																																																										
M	2012	Caprice	Chassis	Electronic Brake Control Module																																																										
M	2012	Caprice	Body	Body Control Module																																																										
M	2012	Caprice	Body	HVAC Control Module																																																										
M	2012	Caprice	Body	Instrument Panel Cluster																																																										
M	2012	Caprice	Body	Passenger Presence System																																																										
M	2012	Caprice	Body	Radio																																																										
M	2012	Caprice	Body	Remote Control Door Lock Receiver																																																										
M	2012	Caprice	Body	Supplemental Inflatable Restraint																																																										
M	2012	Caprice	Body	Theft Deterrent Module																																																										
M	2012	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																								
M	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
M	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
M	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
M	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module	V	V																																																								
M	2012	Spark	Powertrain	1.19L LC5 Engine Control Module	V	V																																																								

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
M	2012	Spark	Powertrain	1.2L L2E Engine Control Module	V	V																																																								
M	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module	V	V																																																								
M	2012	Spark	Powertrain	Transmission Control Module																																																										
M	2012	Spark	Chassis	Electronic Brake Control Module																																																										
M	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2012	Spark	Chassis	Electric Power Steering Control Module																																																										
M	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2012	Spark	Body	Passenger Presence Module																																																										
M	2012	Spark	Body	Instrument Cluster																																																										
M	2013	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
M	2013	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																									V	
M	2013	Caprice	Powertrain	Transmission Control Module																																																										
M	2013	Caprice	Powertrain	Fuel Pump Control Module																																																										
M	2013	Caprice	Chassis	Electronic Brake Control Module																																																										
M	2013	Caprice	Body	Body Control Module																																																										
M	2013	Caprice	Body	HVAC Control Module																																																										
M	2013	Caprice	Body	Instrument Panel Cluster																																																										
M	2013	Caprice	Body	Passenger Presence System																																																										
M	2013	Caprice	Body	Radio																																																										
M	2013	Caprice	Body	Remote Control Door Lock Receiver																																																										
M	2013	Caprice	Body	Supplemental Inflatable Restraint																																																										
M	2013	Caprice	Body	Theft Deterrent Module																																																										
M	2013	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																								
M	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																								
M	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.19L LC5 Engine Control Module	V	V																																																								
M	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module						V																																																				
M	2013	Spark	Powertrain	1.2L L2E Engine Control Module	V	V																																																								
M	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.2L LKY Engine Control Module	V																																																									
M	2013	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																								
M	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2013	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2013	Spark	Chassis	Electronic Brake Control Module																																																										
M	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2013	Spark	Chassis	Power Steering Control Module																																																										
M	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2013	Spark	Body	Body Control Module																																																										
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2013	Spark	Body	Passenger Presence Module																																																										
M	2013	Spark	Body	Instrument Cluster																																																										
M	2013	Spark	Body	Radio																																																										
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
M	2014	Spark	Powertrain	0.8L LBF Engine Control Module	V	V																																																								
M	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V					V																																																			
M	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																								
M	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Transmission Control Module						V																																																				
M	2014	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																								
M	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																								
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module						V																																																				
M	2014	Spark	Powertrain	1.2L LKY Engine Control Module	V																																																									
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																								
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2014	Spark	Chassis	Power Steering Control Module																																																										
M	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2014	Spark	Body	Body Control Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Passenger Presence Module																																																										
M	2014	Spark	Body	Instrument Cluster																																																										
M	2014	Spark	Body	Radio																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark	Body	Keyless Entry Control Module			V																																																							
M	2014	Spark EV	Powertrain	Engine Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2								V																																																		
M	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
M	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2014	Spark EV	Chassis	Power Steering Control Module																																																										
M	2014	Spark EV	Body	Body Control Module																																																										
M	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark EV	Body	Passenger Presence Module																																																										
M	2014	Spark EV	Body	Instrument Cluster																																																										
M	2014	Spark EV	Body	Radio																																																										
M	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
M	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																											
M	2014	Spark EV	Body	Coolant Heater Control Module																																																												
M	2014	Spark EV	Body	Keyless Entry Control Module																																																												
M	2014	Spark EV	Body	Battery Charger Control Module																																																												
M	2014	Spark EV	Body	DC Charging Control Module																																																												
M	2014	Spark EV	Body	Battery Energy Control Module									V	V	V	V	V	V																																														
M	2015	Matiz	Powertrain	1.0L LA2 Engine Control Module	V	V					V																																																					
M	2015	Matiz	Chassis	Electronic Brake Control Module																																																												
M	2015	Matiz	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2015	Matiz	Body	Keyless Entry Control Module			V																																																									
M	2015	Spark	Powertrain	0.8L LBF Engine Control Module	V	V																																																											
M	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																												
M	2015	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V					V																																																					
M	2015	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																											
M	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																												
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																												
M	2015	Spark	Powertrain	1.0L LFM Transmission Control Module						V																																																						
M	2015	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																											
M	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																											
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																													
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
M	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module						V																																																						
M	2015	Spark	Powertrain	1.2L LKY Engine Control Module	V																																																											
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																											
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																													
M	2015	Spark	Powertrain	Fuel Injector Control Module																																																													
M	2015	Spark	Chassis	Electronic Brake Control Module																																																													
M	2015	Spark	Chassis	Electronic Brake Control Module																																																													
M	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																													
M	2015	Spark	Chassis	Power Steering Control Module																																																													
M	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																													
M	2015	Spark	Body	Body Control Module																																																													
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2015	Spark	Body	Passenger Presence Module																																																													
M	2015	Spark	Body	Instrument Cluster																																																													
M	2015	Spark	Body	Instrument Cluster																																																													
M	2015	Spark	Body	Tire Pressure Indicator Module															V	V																																												
M	2015	Spark	Body	Radio																																																												
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																												
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																												
M	2015	Spark	Body	Keyless Entry Control Module			V																																																									
M	2015	Spark EV	Powertrain	Engine Control Module																																																													
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																												
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2								V																																																			
M	2015	Spark EV	Powertrain	Drive Motor Control Module																																																												
M	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
M	2015	Spark EV	Chassis	Electronic Brake Control Module																																																											
M	2015	Spark EV	Chassis	Parking Brake Control Module																																																												
M	2015	Spark EV	Chassis	Power Steering Control Module																																																												
M	2015	Spark EV	Body	Body Control Module																																																												
M	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																												
M	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2015	Spark EV	Body	Passenger Presence Module																																																												
M	2015	Spark EV	Body	Instrument Cluster																																																												
M	2015	Spark EV	Body	Radio																																																											
M	2015	Spark EV	Body	HVAC Control Module																																																												
M	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																												
M	2015	Spark EV	Body	Coolant Heater Control Module																																																												
M	2015	Spark EV	Body	Keyless Entry Control Module																																																												
M	2015	Spark EV	Body	Battery Charger Control Module																																																												
M	2015	Spark EV	Body	DC Charging Control Module																																																												
M	2015	Spark EV	Body	Battery Energy Control Module									V	V	V	V	V																																															
M	2016	Spark	Powertrain	0.8L LBF Engine Control Module	V	V																																																											
M	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																												
M	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																												
M	2016	Spark	Powertrain	1.0L LA2 Engine Control Module	V	V					V																																																					
M	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																												
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																												
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																												
M	2016	Spark	Powertrain	1.0L LCP Engine Control Module	V	V																																																											
M	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												
M	2016	Spark	Powertrain	1.0L LMT Engine Control Module	V	V																																																										
M	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																										
M	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																												
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																												
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																												
M	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module						V																																																						
M	2016	Spark	Powertrain	1.2L LKY Engine Control Module	V																																																											
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module	V	V																																																										
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																												
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																												
M	2016	Spark	Powertrain	Fuel Injector Control Module																																																												
M	2016	Spark	Chassis	Electronic Brake Control Module																																																													
M	2016	Spark	Chassis	Electronic Brake Control Module																																																													
M	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
M	2016	Spark	Chassis	Power Steering Control Module																																																												
M	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
M	2016	Spark	Body	Body Control Module																																																											
M	2016	Spark	Body	Body Control Module																																																											
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2016	Spark	Body	Instrument Cluster																																																											
M	2016	Spark	Body	Instrument Cluster																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
M	2016	Spark	Body	Radio																																																								
M	2016	Spark	Body	Telematics Communication Interface Control Module																																																								
M	2016	Spark	Body	Keyless Entry Control Module			V																																																					
M	2016	Spark EV	Powertrain	Engine Control Module																																																								
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																								
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2								V																																																
M	2016	Spark EV	Powertrain	Drive Motor Control Module																																																								
M	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								
M	2016	Spark EV	Chassis	Electronic Brake Control Module																																																								
M	2016	Spark EV	Chassis	Parking Brake Control Module																																																								
M	2016	Spark EV	Chassis	Power Steering Control Module																																																								
M	2016	Spark EV	Body	Body Control Module																																																								
M	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
M	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2016	Spark EV	Body	Passenger Presence Module																																																								
M	2016	Spark EV	Body	Instrument Cluster																																																								
M	2016	Spark EV	Body	Radio																																																								
M	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																								
M	2016	Spark EV	Body	HVAC Control Module																																																								
M	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																								
M	2016	Spark EV	Body	Coolant Heater Control Module																																																								
M	2016	Spark EV	Body	Keyless Entry Control Module																																																								
M	2016	Spark EV	Body	Frontview Camera Module																																																								
M	2016	Spark EV	Body	Battery Charger Control Module																																																								
M	2016	Spark EV	Body	DC Charging Control Module																																																								
M	2016	Spark EV	Body	Battery Energy Control Module									V	V	V	V	V																																											
N	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																		V	V	V	V	V																		
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																		V	V	V	V	V																		
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																						V	V																	
N	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																						V	V																	
N	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																						V	V																	
N	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																						V	V																	
N	2004	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																								V	V															
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																								
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																								
N	2004	Optra	Body	Remote Function Actuation																																																								
N	2004	Optra	Body	Supplemental Inflatable Restraint																																																								
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
N	2004	Classic	Chassis	Anti-lock Brake System																																																								
N	2004	Classic	Body	Body Control Module																																												V	V											
N	2004	Classic	Body	Radio																																																								
N	2004	Classic	Body	Remote Function Actuation																																																								
N	2004	Classic	Body	Supplemental Inflatable Restraint																																																								
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																								
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Transmission Control Module																																																								
N	2004	Alero (Export)	Chassis	Anti-lock Brake System																																																								
N	2004	Alero (Export)	Body	Body Control Module																																												V	V											
N	2004	Alero (Export)	Body	Instrument Panel Cluster																																													V											
N	2004	Alero (Export)	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
N	2004	Alero (Export)	Body	Supplemental Inflatable Restraint																																																								
N	2004	Alero (Export)	Body	Vehicle Theft Deterrent																																																								
N	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																			V	V	V	V	V																	
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V									V	V								
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																							V	V																
N	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																							V	V																
N	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																							V	V																
N	2005	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V	V																
N	2005	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																									V	V														
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																								
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																								
N	2005	Optra	Body	Remote Function Actuation																																																								
N	2005	Optra	Body	Supplemental Inflatable Restraint																																																								
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
N	2005	Classic	Chassis	Anti-lock Brake System																																																								
N	2005	Classic	Body	Body Control Module																																													V	V										
N	2005	Classic	Body	Radio																																																								
N	2005	Classic	Body	Remote Function Actuation																																																								
N	2005	Classic	Body	Supplemental Inflatable Restraint																																																								
N	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																						V									V	V								
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V									V	V								
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																							V	V																
N	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																							V	V																
N	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																							V	V																
N	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																							V	V																
N	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V	V																
N	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																									V	V														
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																								
N	2006	ALL	Body	Remote Function Actuation																																																								
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																		V						
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																		V						
N	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																						V									V	V								
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V									V	V								
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																							V	V																
N	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																							V																	
N	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																							V																	
N	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																			V	V	V	V	V
N	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																								V											V					
N	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																									V	V														
N	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																								
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																								
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																								
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																								
N	2007	ALL	Chassis	Tire Pressure Monitor																																																								
N	2007	ALL	Body	Remote Function Actuation																																																								

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
N	2007	ALL	Body	Supplemental Inflatable Restraint																																																	V								
N	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																						V									V	V								
N	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V									V	V								
N	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																						V									V	V								
N	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																							V																	
N	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																							V																	
N	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																			V	V	V	V	V
N	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																																																		V	V	V	V	V
N	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V																	
N	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																								
N	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																									V	V														
N	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																							
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																							
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																							
N	2008	ALL	Chassis	Tire Pressure Monitor																																																							
N	2008	ALL	Body	Remote Function Actuation																																																							
N	2008	ALL	Body	Supplemental Inflatable Restraint																																																		V					
N	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																						V									V	V								
N	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V									V	V								
N	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																						V									V	V								
N	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																							V																	
N	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																							V																	
N	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																			V	V	V	V	V
N	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V																	
N	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																								
N	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																									V	V														
N	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																							
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																							
N	2009	ALL	Chassis	Tire Pressure Monitor																																																							
N	2009	ALL	Body	Remote Function Actuation																																																							
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2010	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																						V									V	V								
N	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																						V									V	V								
N	2010	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																							V																	
N	2010	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																			V	V	V	V	V
N	2010	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V																	
N	2010	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2010	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																									V	V														
N	2010	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																							
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																							
N	2010	ALL	Chassis	Tire Pressure Monitor																																																							
N	2010	ALL	Body	Remote Function Actuation																																																							
N	2010	ALL	Body	Remote Function Actuation																																																			V					
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																							
N	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																						V									V	V								

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
N	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																						V								V	V							
N	2011	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																							V															
N	2011	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																	V	V	V	V	V
N	2011	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V															
N	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																					
N	2011	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																										V	V												
N	2011	ALL	Powertrain	Transmission Control Module 5 Speed																																																					
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																					
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																					
N	2011	ALL	Chassis	Tire Pressure Monitor																																																					
N	2011	ALL	Body	Remote Function Actuation																																																					
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																					
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																					
N	2012	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																						V								V	V							
N	2012	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																						V								V	V							
N	2012	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																							V															
N	2012	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																	V	V	V	V	V
N	2012	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																					
N	2012	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																										V	V												
N	2012	ALL	Powertrain	Transmission Control Module 5 Speed																																																					
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																					
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																					
N	2012	ALL	Chassis	Tire Pressure Monitor																																																					
N	2012	ALL	Body	Remote Function Actuation																																																					
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																					
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																					
N	2013	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																						V								V	V							
N	2013	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																						V								V	V							
N	2013	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																							V															
N	2013	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																	V	V	V	V	V
N	2013	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																					
N	2013	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																										V	V												
N	2013	ALL	Powertrain	Transmission Control Module 5 Speed																																																					
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																					
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																					
N	2013	ALL	Chassis	Tire Pressure Monitor																																																					
N	2013	ALL	Body	Remote Function Actuation																																																					
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																					
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																					
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																					
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																					
N	2014	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																					
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																					
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																					
N	2014	Caprice	Powertrain	(2) 6.0L L77 Chassis Control Module																																																					
N	2014	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																					
N	2014	Caprice	Chassis	Electronic Brake Control Module																																																					
N	2014	Caprice	Chassis	Parking Brake Control Module																																																					
N	2014	Caprice	Chassis	Power Steering Control Module																																																					
N	2014	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																					
N	2014	Caprice	Body	Body Control Module																																																					

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
N	2014	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
N	2014	Caprice	Body	Passenger Presence Module																																																									
N	2014	Caprice	Body	Instrument Cluster																																																									
N	2014	Caprice	Body	Radio Controls																																																									
N	2014	Caprice	Body	HVAC Controls																																																									
N	2014	Caprice	Body	Headlamp Control Module																																																									
N	2014	Caprice	Body	Trailer Interface Control Module																																																									
N	2014	Caprice	Body	Radio																																																									
N	2014	Caprice	Body	HVAC Control Module																																																									
N	2014	Caprice	Body	Parking Assist Control Module																				V																																						
N	2014	Caprice	Body	Frontview Camera Module																					V																																					
N	2014	Caprice	Body	Steering Column Lock Control Module																																																									
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
N	2015	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																									
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																									
N	2015	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																									
N	2015	Caprice	Powertrain	Fuel Injector Control Module																																																									
N	2015	Caprice	Chassis	Electronic Brake Control Module																																																									
N	2015	Caprice	Chassis	Parking Brake Control Module																																																									
N	2015	Caprice	Chassis	Power Steering Control Module																																																									
N	2015	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2015	Caprice	Chassis	Suspension Control Module																							V	V																																		
N	2015	Caprice	Body	Body Control Module																																																									
N	2015	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2015	Caprice	Body	Passenger Presence Module																																																									
N	2015	Caprice	Body	Instrument Cluster																																																									
N	2015	Caprice	Body	Head-Up Display Module																																																									
N	2015	Caprice	Body	Radio Controls																																																									
N	2015	Caprice	Body	HVAC Controls																																																									
N	2015	Caprice	Body	Headlamp Control Module																																																									
N	2015	Caprice	Body	Trailer Interface Control Module																																																									
N	2015	Caprice	Body	Radio																																																									
N	2015	Caprice	Body	Telematics Communication Interface Control Module																																																									
N	2015	Caprice	Body	HVAC Control Module																																																									
N	2015	Caprice	Body	Right Side Object Detection Control Module																																																									
N	2015	Caprice	Body	Left Side Object Detection Control Module																																																									
N	2015	Caprice	Body	Parking Assist Control Module																				V																																						
N	2015	Caprice	Body	Frontview Camera Module																					V																																					
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
N	2016	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																									
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																									
N	2016	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																									
N	2016	Caprice	Powertrain	Fuel Injector Control Module																																																									
N	2016	Caprice	Chassis	Electronic Brake Control Module																																																									
N	2016	Caprice	Chassis	Parking Brake Control Module																																																									
N	2016	Caprice	Chassis	Power Steering Control Module																																																									
N	2016	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																									

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
N	2016	Caprice	Chassis	Suspension Control Module																																																											
N	2016	Caprice	Body	Body Control Module																																																											
N	2016	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2016	Caprice	Body	Passenger Presence Module																																																											
N	2016	Caprice	Body	Instrument Cluster																																																											
N	2016	Caprice	Body	Head-Up Display Module																																																											
N	2016	Caprice	Body	Radio Controls																																																											
N	2016	Caprice	Body	HVAC Controls																																																											
N	2016	Caprice	Body	Trailer Interface Control Module																																																											
N	2016	Caprice	Body	Radio																																																											
N	2016	Caprice	Body	Telematics Communication Interface Control Module																																																											
N	2016	Caprice	Body	HVAC Control Module																																																											
N	2016	Caprice	Body	Seat Memory Control Module - Driver																																																											
N	2016	Caprice	Body	Right Side Object Detection Control Module																																																											
N	2016	Caprice	Body	Left Side Object Detection Control Module																																																											
N	2016	Caprice	Body	Parking Assist Control Module																				V																																								
N	2016	Caprice	Body	Frontview Camera Module																																																												
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																											
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																											
P	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																											
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																											
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																											
P	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																											
P	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																											
P	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																											
P	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																											
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																											
P	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																											
P	2010	Cruze	Chassis	Electronic Brake Control Module																																																											
P	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2010	Cruze	Body	Body Control Module																																																											
P	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2010	Cruze	Body	Passenger Presence Module																																																											
P	2010	Cruze	Body	Instrument Cluster																																																											
P	2010	Cruze	Body	Trailer Interface Control Module																																																											
P	2010	Cruze	Body	Radio																																																											
P	2010	Cruze	Body	Multimedia Player Interface Module																																																											
P	2010	Cruze	Body	Mobile Telephone Control Module																																																											
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2010	Cruze	Body	Keyless Entry Control Module																																																											
P	2010	Cruze	Body	Parking Assist Control Module																																																											
P	2010	Cruze	Body	Steering Column Lock Control Module																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																										
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																										
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																										
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																										
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																										
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																										
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																										
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																										
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																										
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																										
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																										
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																										
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2011	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2011	Cruze	Body	Body Control Module																																																										
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2011	Cruze	Body	Passenger Presence Module																																																										
P	2011	Cruze	Body	Instrument Cluster																																																										
P	2011	Cruze	Body	Trailer Interface Control Module																																																										
P	2011	Cruze	Body	Radio																																																										
P	2011	Cruze	Body	Multimedia Player Interface Module																																																										
P	2011	Cruze	Body	Mobile Telephone Control Module																																																										
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
P	2011	Cruze	Body	Keyless Entry Control Module																																																										
P	2011	Cruze	Body	Parking Assist Control Module																																																										
P	2011	Cruze	Body	Steering Column Lock Control Module																																																										
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																										
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																										
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
P	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																												
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																												
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																												
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																												
P	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																												
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																												
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																												
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																												
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																												
P	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
P	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
P	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																												
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																												
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																												
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																												
P	2012	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2012	Cruze	Body	Body Control Module Hatchback																																																												
P	2012	Cruze	Body	Body Control Module Sedan																																																												
P	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2012	Cruze	Body	Passenger Presence Module																																																												
P	2012	Cruze	Body	Instrument Cluster																																																												
P	2012	Cruze	Body	Trailer Interface Control Module																																																												
P	2012	Cruze	Body	Radio																																																											
P	2012	Cruze	Body	Multimedia Player Interface Module																																																											
P	2012	Cruze	Body	Mobile Telephone Control Module																																																											
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2012	Cruze	Body	Keyless Entry Control Module																																																											
P	2012	Cruze	Body	Parking Assist Control Module																																																											
P	2012	Cruze	Body	Steering Column Lock Control Module																																																											
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																										V																																
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																										V																																
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																										V																																
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2013	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2013	Cruze	Body	Body Control Module Hatchback																																																										
P	2013	Cruze	Body	Body Control Module Sedan																																																										
P	2013	Cruze	Body	Body Control Module Station Wagon																																																										
P	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2013	Cruze	Body	Passenger Presence Module																																																										
P	2013	Cruze	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
P	2013	Cruze	Body	Trailer Interface Control Module																																																											
P	2013	Cruze	Body	Radio																																																											
P	2013	Cruze	Body	Digital Radio Receiver Control Module																																																											
P	2013	Cruze	Body	Multimedia Player Interface Module																																																											
P	2013	Cruze	Body	Mobile Telephone Control Module																																																											
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																											
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																											
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																											
P	2013	Cruze	Body	Front Seat Heating Control Module																																																											
P	2013	Cruze	Body	Keyless Entry Control Module																																																											
P	2013	Cruze	Body	Right Side Object Detection Control Module																																																											
P	2013	Cruze	Body	Left Side Object Detection Control Module																																																											
P	2013	Cruze	Body	Parking Assist Control Module																																																											
P	2013	Cruze	Body	Steering Column Lock Control Module																																																											
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																										V																																	
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																											
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																											
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																											
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																											
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																											
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																											
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																										V																																	
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																											
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																											
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																											
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																											
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																											
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																											
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																											
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																											
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																											
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																										V																																		
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																										V																																		
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																												
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																												
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																										V																																		
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																												
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																												
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																												
P	2014	Cruze	Powertrain	Fuel Injector Control Module																																																												
P	2014	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2014	Cruze	Chassis	Power Steering Control Module																																																												
P	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2014	Cruze	Body	Body Control Module Hatchback																																																												
P	2014	Cruze	Body	Body Control Module Sedan																																																												
P	2014	Cruze	Body	Body Control Module Station Wagon																																																												
P	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2014	Cruze	Body	Passenger Presence Module																																																												
P	2014	Cruze	Body	Instrument Cluster																																																												
P	2014	Cruze	Body	Trailer Interface Control Module																																																												
P	2014	Cruze	Body	Radio																																																											
P	2014	Cruze	Body	Digital Radio Receiver Control Module																																																												
P	2014	Cruze	Body	Multimedia Player Interface Module																																																												
P	2014	Cruze	Body	Mobile Telephone Control Module																																																												
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
P	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																												
P	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																												
P	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																												
P	2014	Cruze	Body	Front Seat Heating Control Module																																																												
P	2014	Cruze	Body	Keyless Entry Control Module																																																												
P	2014	Cruze	Body	Right Side Object Detection Control Module																																																												
P	2014	Cruze	Body	Left Side Object Detection Control Module																																																												
P	2014	Cruze	Body	Parking Assist Control Module																																																												
P	2014	Cruze	Body	Steering Column Lock Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																										V																																		
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																												
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																										V																																		
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																										V																																			
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																												
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																										V																																			
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																										V																																
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																										V																																
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																										
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																										
P	2015	Cruze	Powertrain	Fuel Injector Control Module																																																										
P	2015	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2015	Cruze	Chassis	Power Steering Control Module																																																										
P	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2015	Cruze	Body	Body Control Module Hatchback																																																										
P	2015	Cruze	Body	Body Control Module Sedan																																																										
P	2015	Cruze	Body	Body Control Module Station Wagon																																																										
P	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2015	Cruze	Body	Passenger Presence Module																																																										
P	2015	Cruze	Body	Instrument Cluster																																																										
P	2015	Cruze	Body	Trailer Interface Control Module																																																										
P	2015	Cruze	Body	Radio																																																										
P	2015	Cruze	Body	Digital Radio Receiver Control Module																																																										
P	2015	Cruze	Body	Multimedia Player Interface Module																																																										
P	2015	Cruze	Body	Mobile Telephone Control Module																																																										
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
P	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
P	2015	Cruze	Body	Front Seat Heating Control Module																																																										
P	2015	Cruze	Body	Keyless Entry Control Module																																																										
P	2015	Cruze	Body	Right Side Object Detection Control Module																																																										
P	2015	Cruze	Body	Left Side Object Detection Control Module																																																										
P	2015	Cruze	Body	Parking Assist Control Module																				V																																						
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
P	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																											
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2016	Cruze	Powertrain	Fuel Injector Control Module																																																												
P	2016	Cruze	Powertrain	Chassis Control Module																																																												
P	2016	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2016	Cruze	Chassis	Power Steering Control Module																																																												
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2016	Cruze	Body	Body Control Module Hatchback																																																												
P	2016	Cruze	Body	Body Control Module Sedan																																																												
P	2016	Cruze	Body	Body Control Module Station Wagon																																																												
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2016	Cruze	Body	Passenger Presence Module																																																												
P	2016	Cruze	Body	Instrument Cluster																																																												
P	2016	Cruze	Body	Trailer Interface Control Module																																																												
P	2016	Cruze	Body	Radio Other																																																											
P	2016	Cruze	Body	Radio (UF7)																																																											
P	2016	Cruze	Body	Multimedia Player Interface Module																																																											
P	2016	Cruze	Body	Mobile Telephone Control Module																																																											
P	2016	Cruze	Body	Telematics Communication Interface Control Module																																																											
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																											
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																											
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																											
P	2016	Cruze	Body	Front Seat Heating Control Module																																																											
P	2016	Cruze	Body	Keyless Entry Control Module																																																											
P	2016	Cruze	Body	Right Side Object Detection Control Module																																																											
P	2016	Cruze	Body	Left Side Object Detection Control Module																																																											
P	2016	Cruze	Body	Parking Assist Control Module																																																											
P	2016	Cruze	Body	Steering Column Lock Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2011	Volt	Powertrain	Engine Control Module																																																											
R	2011	Volt	Powertrain	Trasmission Control Module																																																												
R	2011	Volt	Powertrain	Fuel Pump Control Module																																																												
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module																																																												
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																												
R	2011	Volt	Powertrain	Drive Motor Control Module 1																																																												
R	2011	Volt	Powertrain	Drive Motor Control Module 2																																																												
R	2011	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2011	Volt	Chassis	Electronic Brake Control Module																																																												
R	2011	Volt	Chassis	Parking Brake Control Module																																																												
R	2011	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
R	2011	Volt	Chassis	Power Steering Control Module																																																												
R	2011	Volt	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2011	Volt	Body	Body Control Module																																																												
R	2011	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2011	Volt	Body	Passenger Presence Module																																																												
R	2011	Volt	Body	Instrument Cluster																																																												
R	2011	Volt	Body	Radio																																																												
R	2011	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2011	Volt	Body	Mobile Telephone Control Module																																																												
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2011	Volt	Body	Remote Heater and Air Conditioning Control Module																																																												
R	2011	Volt	Body	Electric A/C Compressor Control Module																																																												
R	2011	Volt	Body	Coolant Heater Control Module																																																												
R	2011	Volt	Body	Keyless Entry Control Module																																																												
R	2011	Volt	Body	Parking Assist Control Module																																																												
R	2011	Volt	Body	Steering Column Lock Control Module																																																												
R	2011	Volt	Body	Battery Charger Control Module																																																												
R	2011	Volt	Body	Battery Energy Control Module																																																												
R	2012	Volt	Powertrain	Engine Control Module																																																												
R	2012	Volt	Powertrain	Trasmission Control Module																																																												
R	2012	Volt	Powertrain	Fuel Pump Control Module																																																												
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module																																																												
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																												
R	2012	Volt	Powertrain	Drive Motor Control Module 1																																																												
R	2012	Volt	Powertrain	Drive Motor Control Module 2																																																												
R	2012	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2012	Volt	Chassis	Electronic Brake Control Module																																																												
R	2012	Volt	Chassis	Parking Brake Control Module																																																												
R	2012	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
R	2012	Volt	Chassis	Power Steering Control Module																																																												
R	2012	Volt	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2012	Volt	Body	Body Control Module																																																												
R	2012	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2012	Volt	Body	Passenger Presence Module																																																												
R	2012	Volt	Body	Instrument Cluster																																																												
R	2012	Volt	Body	Radio																																																												
R	2012	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2012	Volt	Body	Mobile Telephone Control Module																																																												
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 9																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2012	Volt	Body	Remote Heater and Air Conditioning Control Module																																																										
R	2012	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2012	Volt	Body	Coolant Heater Control Module																																																										
R	2012	Volt	Body	Keyless Entry Control Module																																																										
R	2012	Volt	Body	Parking Assist Control Module																																																										
R	2012	Volt	Body	Steering Column Lock Control Module																																																										
R	2012	Volt	Body	Battery Charger Control Module																																																										
R	2012	Volt	Body	Battery Energy Control Module																																																										
R	2013	Volt	Powertrain	Engine Control Module																																																										
R	2013	Volt	Powertrain	Trasmission Control Module																																																										
R	2013	Volt	Powertrain	Fuel Pump Control Module																																																										
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2013	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2013	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2013	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2013	Volt	Chassis	Electronic Brake Control Module																																																										
R	2013	Volt	Chassis	Parking Brake Control Module																																																										
R	2013	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2013	Volt	Chassis	Power Steering Control Module																																																										
R	2013	Volt	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2013	Volt	Body	Body Control Module																																																										
R	2013	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2013	Volt	Body	Passenger Presence Module																																																										
R	2013	Volt	Body	Instrument Cluster																																																										
R	2013	Volt	Body	Radio																																																										
R	2013	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2013	Volt	Body	Multimedia Player Interface Module																																																										
R	2013	Volt	Body	Mobile Telephone Control Module																																																										
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2013	Volt	Body	HVAC Control Module																																																										
R	2013	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2013	Volt	Body	Coolant Heater Control Module																																																										
R	2013	Volt	Body	Front Seat Heating Control Module																																																										
R	2013	Volt	Body	Keyless Entry Control Module																																																										
R	2013	Volt	Body	Parking Assist Control Module																																																										
R	2013	Volt	Body	Frontview Camera Module																					V																																					
R	2013	Volt	Body	Steering Column Lock Control Module																																																										
R	2013	Volt	Body	Battery Charger Control Module																																																										
R	2013	Volt	Body	Battery Energy Control Module																																																										
R	2014	Volt	Powertrain	Engine Control Module																																																										
R	2014	Volt	Powertrain	Trasmission Control Module																																																										
R	2014	Volt	Powertrain	Chassis Control Module																																																										
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2014	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2014	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2014	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2014	Volt	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2014	Volt	Chassis	Parking Brake Control Module																																																											
R	2014	Volt	Chassis	Power Steering Control Module																																																												
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2014	Volt	Body	Body Control Module																																																												
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Volt	Body	Passenger Presence Module																																																												
R	2014	Volt	Body	Instrument Cluster																																																												
R	2014	Volt	Body	Radio																																																												
R	2014	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Volt	Body	HVAC Control Module																																																												
R	2014	Volt	Body	Electric A/C Compressor Control Module																																																												
R	2014	Volt	Body	Coolant Heater Control Module																																																												
R	2014	Volt	Body	Front Seat Heating Control Module																																																												
R	2014	Volt	Body	Keyless Entry Control Module																																																												
R	2014	Volt	Body	Parking Assist Control Module																																																												
R	2014	Volt	Body	Frontview Camera Module																					V																																								
R	2014	Volt	Body	Steering Column Lock Control Module																																																												
R	2014	Volt	Body	Battery Charger Control Module																																																												
R	2014	Volt	Body	Battery Energy Control Module																																																												
R	2015	Volt	Powertrain	Engine Control Module																																																												
R	2015	Volt	Powertrain	Trasmission Control Module																																																												
R	2015	Volt	Powertrain	Chassis Control Module																																																												
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module																																																												
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																												
R	2015	Volt	Powertrain	Drive Motor Control Module 1																																																												
R	2015	Volt	Powertrain	Drive Motor Control Module 2																																																												
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2015	Volt	Chassis	Electronic Brake Control Module																																																												
R	2015	Volt	Chassis	Parking Brake Control Module																																																												
R	2015	Volt	Chassis	Power Steering Control Module																																																												
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2015	Volt	Body	Body Control Module																																																												
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Volt	Body	Passenger Presence Module																																																												
R	2015	Volt	Body	Instrument Cluster																																																												
R	2015	Volt	Body	Radio																																																												
R	2015	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2015	Volt	Body	Telematics Communication Interface Control Module																																																												
R	2015	Volt	Body	HVAC Control Module																																																												
R	2015	Volt	Body	Electric A/C Compressor Control Module																																																												
R	2015	Volt	Body	Coolant Heater Control Module																																																												
R	2015	Volt	Body	Front Seat Heating Control Module																																																												
R	2015	Volt	Body	Keyless Entry Control Module																																																												
R	2015	Volt	Body	Parking Assist Control Module																				V																																								
R	2015	Volt	Body	Frontview Camera Module																					V																																								
R	2015	Volt	Body	Steering Column Lock Control Module																																																												
R	2015	Volt	Body	Battery Charger Control Module																																																												
R	2015	Volt	Body	Battery Energy Control Module																																																												
R	2016	Volt	Powertrain	Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2016	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2016	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2016	Volt	Chassis	Electronic Brake Control Module																																																										
R	2016	Volt	Chassis	Brake Booster Control Module																																																										
R	2016	Volt	Chassis	Power Steering Control Module																																																										
R	2016	Volt	Body	Body Control Module																																																										
R	2016	Volt	Body	Pedestrian Alert Sound Control Module																																																										
R	2016	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Volt	Body	Passenger Presence Module																																																										
R	2016	Volt	Body	Instrument Cluster																																																										
R	2016	Volt	Body	Radio Controls																																																										
R	2016	Volt	Body	HVAC Controls																																																										
R	2016	Volt	Body	Radio																																																										
R	2016	Volt	Body	Amplifier																																																										
R	2016	Volt	Body	Human Machine Interface Control Module																																																										
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 9.7																																																										
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2016	Volt	Body	HVAC Control Module																																																										
R	2016	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2016	Volt	Body	Keyless Entry Control Module																																																										
R	2016	Volt	Body	Right Side Object Detection Control Module																																																										
R	2016	Volt	Body	Left Side Object Detection Control Module																																																										
R	2016	Volt	Body	Parking Assist Control Module					V																																																					
R	2016	Volt	Body	Frontview Camera Module																																																										
R	2016	Volt	Body	Steering Column Lock Control Module																																																										
R	2016	Volt	Body	Battery Energy Control Module																																																										
R	2016	Volt	Body	Long Range Radar Sensor Module																																																										
S	2004	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2004	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																		V	V	V	V	V																				
S	2004	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																						V	V																			
S	2004	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																						V	V																			
S	2004	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																						V	V																			
S	2004	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V	V																			
S	2004	Aveo	Powertrain	Transmission Control Module																																																										
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2004	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2004	Aveo	Body	Remote Function Actuation																																																										
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2005	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																		V	V	V	V	V																				
S	2005	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																						V	V																			
S	2005	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																						V	V																			
S	2005	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																						V	V																			
S	2005	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V	V																			
S	2005	Aveo	Powertrain	Transmission Control Module																																																										
S	2005	Aveo	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2005	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2005	Aveo	Body	Remote Function Actuation																																																										
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2006	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																						V									V	V										
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V	V																		
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																							V	V																		
S	2006	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																							V	V																		
S	2006	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																							V	V																		
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																								V													V					
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																							V	V																		
S	2006	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2006	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2006	Aveo	Body	Supplemental Inflatable Restraint																																																				V						
S	2006	Aveo	Body	Remote Function Actuation																																																										
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2007	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																						V									V	V										
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V																			
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																							V	V																		
S	2007	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																							V																			
S	2007	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																							V																			
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																								V													V					
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																							V	V																		
S	2007	Aveo	Powertrain	Transmission Control Module 4 Speed																																																										
S	2007	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2007	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2007	Aveo	Body	Supplemental Inflatable Restraint																																																				V						
S	2007	Aveo	Body	Remote Function Actuation																																																										
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2008	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																							V										V									
S	2008	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																						V									V	V										
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V																			
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																							V	V																		
S	2008	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																				V						
S	2008	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																							V																			
S	2008	Aveo	Powertrain	(V)1.6L L4 LLQ Engine Control Module India																																							V	V																		
S	2008	Aveo	Powertrain	Transmission Control Module																																																										
S	2008	Aveo	Powertrain	Transmission Control Module																																																										
S	2008	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2008	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2008	Aveo	Body	Supplemental Inflatable Restraint																																																				V						
S	2008	Aveo	Body	Remote Function Actuation																																																										
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2009	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																							V										V									
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V																			
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																							V	V																		
S	2009	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																				V						
S	2009	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																							V																			

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2009	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
S	2009	Aveo	Powertrain	Transmission Control Module																																																										
S	2009	Aveo	Powertrain	Transmission Control Module																																																										
S	2009	Aveo	Powertrain	Other Auto Transmission System																																																										
S	2009	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2009	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2009	Aveo	Body	Supplemental Inflatable Restraint																																																				V						
S	2009	Aveo	Body	Remote Function Actuation																																																										
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2010	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																							V										V									
S	2010	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																								V																		
S	2010	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																						V				
S	2010	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																								V																		
S	2010	Aveo	Powertrain	(6)1.6L L4 LXT Engine Control Module																																								V																		
S	2010	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2010	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2010	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2010	Aveo	Body	Supplemental Inflatable Restraint																																																				V						
S	2010	Aveo	Body	Remote Function Actuation																																																										
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																												V	V																													
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																												V																														
S	2010	Sail	Powertrain	1.4L LCU Engine Control Module																												V																														
S	2010	Sail	Powertrain	Transmission Control Module																													V	V																												
S	2010	Sail	Chassis	Electronic Brake Control Module																																																										
S	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																											
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2011	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																							V										V									
S	2011	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																								V																		
S	2011	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																						V				
S	2011	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																								V																		
S	2011	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
S	2011	Aveo	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																										
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2011	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2011	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2011	Aveo	Body	Supplemental Inflatable Restraint																																																				V						
S	2011	Aveo	Body	Remote Function Actuation																																																										
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																												V	V																													
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																												V																														
S	2011	Sail	Powertrain	1.4L LCU Engine Control Module																												V																														
S	2011	Sail	Powertrain	Transmission Control Module																													V	V																												
S	2011	Sail	Chassis	Electronic Brake Control Module																																																										
S	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																											
S	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																								V									V									
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
S	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
S	2012	Aveo	Powertrain	Fuel Pump Control Module																																																										
S	2012	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	Aveo	Chassis	Electric Power Steering Control Module																																																										
S	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2012	Aveo	Chassis	Tire Pressure Monitor																																																										
S	2012	Aveo	Body	Body Control Module Hatchback																																																										
S	2012	Aveo	Body	Body Control Module Sedan																																																										
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	Aveo	Body	Passenger Presence Module																																																										
S	2012	Aveo	Body	Instrument Cluster																																																										
S	2012	Aveo	Body	Radio																																																										
S	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
S	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2012	Aveo	Body	Front Seat Heating Control Module																																																										
S	2012	Aveo	Body	Remote Function Actuation																																																										
S	2012	Aveo	Body	Parking Assist Control Module																																																										
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																												V	V																													
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																												V																															
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																												V	V																													
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																												V																															
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																												V																															
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																												V				V																											
S	2012	Sail	Powertrain	Transmission Control Module																													V	V																													
S	2012	Sail	Chassis	Electronic Brake Control Module																																																										
S	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																												
S	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																							V									V										
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																								V																		
S	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																			V						
S	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																								V																		
S	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																								V																		
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
S	2013	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2013	Aveo	Powertrain	Fuel Pump Control Module																																																										
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2013	Aveo	Chassis	Electric Power Steering Control Module																																																										
S	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2013	Aveo	Body	Body Control Module Hatchback																																																										
S	2013	Aveo	Body	Body Control Module Sedan																																																										
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																		V							
S	2013	Aveo	Body	Passenger Presence Module																																																										
S	2013	Aveo	Body	Instrument Cluster																																																										
S	2013	Aveo	Body	Radio																																																										
S	2013	Aveo	Body	Telematics Communication Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
S	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
S	2013	Aveo	Body	Front Seat Heating Control Module																																																												
S	2013	Aveo	Body	Remote Function Actuation																																																												
S	2013	Aveo	Body	Parking Assist Control Module																																																												
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																											V	V																																
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																											V																																	
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																											V																																	
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																											V					V																											
S	2013	Sail	Powertrain	Transmission Control Module																												V	V																														
S	2013	Sail	Chassis	Electronic Brake Control Module																																																											
S	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																											
S	2014	Aveo	Powertrain	1.2L LMU Engine Control Module	V	V					V																																																				
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																											
S	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																											
S	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																											
S	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																											
S	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
S	2014	Aveo	Powertrain	Chassis Control Module																																																											
S	2014	Aveo	Powertrain	Fuel Injector Control Module																																																											
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2014	Aveo	Chassis	Power Steering Control Module																																																											
S	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2014	Aveo	Body	Body Control Module Hatchback																																																											
S	2014	Aveo	Body	Body Control Module Sedan																																																											
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2014	Aveo	Body	Instrument Cluster																																																											
S	2014	Aveo	Body	Radio																																																											
S	2014	Aveo	Body	Telematics Communication Interface Control Module																																																											
S	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
S	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
S	2014	Aveo	Body	Front Seat Heating Control Module																																																											
S	2014	Aveo	Body	Keyless Entry Control Module			V																																																								
S	2014	Aveo	Body	Parking Assist Control Module																																																											
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																												V	V																													
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																												V																														
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																												V																														
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																												V				V																										
S	2014	Sail	Powertrain	Transmission Control Module																													V	V																												
S	2014	Sail	Chassis	Electronic Brake Control Module																																																											
S	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																												
S	2015	Aveo	Powertrain	1.2L LMU Engine Control Module	V	V					V																																																				
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																											
S	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
S	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
S	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
S	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
S	2015	Aveo	Powertrain	Chassis Control Module																																																										
S	2015	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2015	Aveo	Chassis	Power Steering Control Module																																																										
S	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	Aveo	Body	Body Control Module Hatchback																																																										
S	2015	Aveo	Body	Body Control Module Sedan																																																										
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Aveo	Body	Instrument Cluster																																																										
S	2015	Aveo	Body	Radio																																																										
S	2015	Aveo	Body	Telematics Communication Interface Control Module																																																										
S	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2015	Aveo	Body	Front Seat Heating Control Module																																																										
S	2015	Aveo	Body	Keyless Entry Control Module			V																																																							
S	2015	Aveo	Body	Parking Assist Control Module																																																										
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																												V	V																													
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																												V																														
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																												V																														
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																												V				V																										
S	2015	Sail	Powertrain	Transmission Control Module																													V	V																												
S	2015	Sail	Chassis	Electronic Brake Control Module																																																										
S	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																											
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
S	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
S	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
S	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
S	2016	Aveo	Powertrain	Chassis Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Power Steering Control Module																																																										
S	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	Aveo	Body	Body Control Module Hatchback																																																										
S	2016	Aveo	Body	Body Control Module Sedan																																																										
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Body	Instrument Cluster																																																										
S	2016	Aveo	Body	Radio																																																										
S	2016	Aveo	Body	Telematics Communication Interface Control Module																																																										
S	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2016	Aveo	Body	Front Seat Heating Control Module																																																										
S	2016	Aveo	Body	Parking Assist Control Module																																																										
S	2016	Aveo	Body	Keyless Entry Control Module			V																																																							
S	2016	Aveo	Body	Frontview Camera Module																																																										
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																												V	V																													
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																												V																														

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																										
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																												V																														
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																												V				V																										
S	2016	Sail	Powertrain	Transmission Control Module																													V	V																												
S	2016	Sail	Chassis	Electronic Brake Control Module																																																									
S	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																										
T	2004	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																			V	V	V	V	V																	
T	2004	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V	V																
T	2004	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																							V	V																
T	2004	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																							V	V																
T	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																							V	V																
T	2004	ALL	Powertrain	Transmission Control Module																																																									
T	2004	ALL	Chassis	Electronic Brake Control Module																																																									
T	2004	ALL	Chassis	Electronic Brake Control Module																																																									
T	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2004	ALL	Body	Remote Function Actuation																																																									
T	2005	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																			V	V	V	V	V																	
T	2005	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V	V																
T	2005	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																							V	V																
T	2005	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																							V	V																
T	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																							V	V																
T	2005	ALL	Powertrain	Transmission Control Module																																																									
T	2005	ALL	Chassis	Electronic Brake Control Module																																																									
T	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2005	ALL	Body	Remote Function Actuation																																																									
T	2006	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																						V										V	V							
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V	V																
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																							V	V																
T	2006	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																							V	V																
T	2006	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																							V	V																
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																								V												V				
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																							V	V																
T	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2006	ALL	Chassis	Electronic Brake Control Module																																																									
T	2006	ALL	Body	Supplemental Inflatable Restraint																																																			V					
T	2006	ALL	Body	Remote Function Actuation																																																								
T	2007	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																						V										V	V							
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																							V																	
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																							V	V																
T	2007	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																							V																	
T	2007	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																							V																	
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																								V											V				
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																							V	V																
T	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																									
T	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2007	ALL	Chassis	Electronic Brake Control Module																																																									
T	2007	ALL	Body	Supplemental Inflatable Restraint																																																			V					
T	2007	ALL	Body	Remote Function Actuation																																																									
T	2008	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																						V											V							
T	2008	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																						V										V	V							
T	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																							V	V																

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2008	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																											
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																												
T	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																												
T	2008	ALL	Powertrain	Transmission Control Module																																																												
T	2008	ALL	Powertrain	Transmission Control Module																																																												
T	2008	ALL	Chassis	Electronic Brake Control Module																																																												
T	2008	ALL	Chassis	Tire Pressure Monitor																																																												
T	2008	ALL	Body	Supplemental Inflatable Restraint																																																			V								
T	2008	ALL	Body	Remote Function Actuation																																																											
T	2008	ALL	Body	Passenger Presence System																																																												
T	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																								V	V																		
T	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																								V																		
T	2009	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																												
T	2009	ALL	Powertrain	Transmission Control Module																																																												
T	2009	ALL	Powertrain	Transmission Control Module																																																												
T	2009	ALL	Chassis	Electronic Brake Control Module																																																												
T	2009	ALL	Chassis	Tire Pressure Monitor																																																												
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																		V								
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2009	ALL	Body	Instrument Panel Cluster																																																												
T	2009	ALL	Body	Passenger Presence System																																																												
T	2009	ALL	Body	Theft Deterrent Module																																																												
T	2009	ALL	Body	Radio																																																												
T	2009	ALL	Body	Remote Function Actuation																																																												
T	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																								V																		
T	2010	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																		V								
T	2010	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																												
T	2010	ALL	Powertrain	Transmission Control Module																																																												
T	2010	ALL	Powertrain	Transmission Control Module																																																												
T	2010	ALL	Chassis	Electronic Brake Control Module																																																												
T	2010	ALL	Chassis	Tire Pressure Monitor																																																												
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																		V								
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2010	ALL	Body	Instrument Panel Cluster																																																												
T	2010	ALL	Body	Passenger Presence System																																																												
T	2010	ALL	Body	Theft Deterrent Module																																																												
T	2010	ALL	Body	Radio																																																												
T	2010	ALL	Body	Remote Function Actuation																																																												
T	2011	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																							V									V									
T	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																								V																		
T	2011	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																		V								
T	2011	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																								V																		
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																								V																		
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module Argentia																																									V																		
T	2011	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																												
T	2011	ALL	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																												
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
T	2011	ALL	Chassis	Electronic Brake Control Module																																																												
T	2011	ALL	Chassis	Tire Pressure Monitor																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																		V							
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2011	ALL	Body	Instrument Panel Cluster																																																									
T	2011	ALL	Body	Passenger Presence System																																																									
T	2011	ALL	Body	Theft Deterrent Module																																																									
T	2011	ALL	Body	Radio																																																									
T	2011	ALL	Body	Remote Function Actuation																																																									
T	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																							V									V							
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
T	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																								V																	
T	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																			V					
T	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																								V																	
T	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																								V																	
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																									
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																									
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
T	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
T	2012	Aveo	Powertrain	Fuel Injector Control Module																																																									
T	2012	Aveo	Powertrain	Fuel Pump Control Module																																																									
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2012	Aveo	Chassis	Electric Power Steering Control Module																																																									
T	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2012	Aveo	Chassis	Tire Pressure Monitor																																																									
T	2012	Aveo	Body	Body Control Module Hatchback																																																									
T	2012	Aveo	Body	Body Control Module Sedan																																																									
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2012	Aveo	Body	Passenger Presence Module																																																									

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2012	Aveo	Body	Instrument Cluster																																																										
T	2012	Aveo	Body	Radio																																																										
T	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
T	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2012	Aveo	Body	Front Seat Heating Control Module																																																										
T	2012	Aveo	Body	Remote Function Actuation																																																										
T	2012	Aveo	Body	Parking Assist Control Module																																																										
T	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
T	2013	Aveo	Powertrain	Fuel Injector Control Module																																																										
T	2013	Aveo	Powertrain	Fuel Pump Control Module																																																										
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	Aveo	Chassis	Electric Power Steering Control Module																																																										
T	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2013	Aveo	Body	Body Control Module Hatchback																																																										
T	2013	Aveo	Body	Body Control Module Sedan																																																										
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	Aveo	Body	Passenger Presence Module																																																										
T	2013	Aveo	Body	Instrument Cluster																																																										
T	2013	Aveo	Body	Radio																																																										
T	2013	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2013	Aveo	Body	Front Seat Heating Control Module																																																											
T	2013	Aveo	Body	Remote Function Actuation																																																												
T	2013	Aveo	Body	Parking Assist Control Module																																																												
T	2014	Aveo	Powertrain	1.2L LMU Engine Control Module	V	V					V																																																					
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																												
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																												
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
T	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
T	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																												
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																												
T	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																												
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
T	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																												
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
T	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
T	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
T	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
T	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
T	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
T	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
T	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
T	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
T	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
T	2014	Aveo	Powertrain	Chassis Control Module																																																												
T	2014	Aveo	Powertrain	Fuel Injector Control Module																																																												
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2014	Aveo	Chassis	Power Steering Control Module																																																												
T	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2014	Aveo	Body	Body Control Module Hatchback																																																												
T	2014	Aveo	Body	Body Control Module Sedan																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2014	Aveo	Body	Instrument Cluster																																																												
T	2014	Aveo	Body	Radio																																																												
T	2014	Aveo	Body	Telematics Communication Interface Control Module																																																												
T	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
T	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
T	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
T	2014	Aveo	Body	Front Seat Heating Control Module																																																												
T	2014	Aveo	Body	Keyless Entry Control Module			V																																																								
T	2014	Aveo	Body	Parking Assist Control Module																																																												
T	2015	Aveo	Powertrain	1.2L LMU Engine Control Module	V	V					V																																																					
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
T	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																												
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																												
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
T	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
T	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
T	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
T	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
T	2015	Aveo	Powertrain	Chassis Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2015	Aveo	Powertrain	Fuel Injector Control Module																																																											
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2015	Aveo	Chassis	Power Steering Control Module																																																												
T	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2015	Aveo	Body	Body Control Module Hatchback																																																												
T	2015	Aveo	Body	Body Control Module Sedan																																																												
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2015	Aveo	Body	Instrument Cluster																																																												
T	2015	Aveo	Body	Radio																																																												
T	2015	Aveo	Body	Telematics Communication Interface Control Module																																																												
T	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
T	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
T	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
T	2015	Aveo	Body	Front Seat Heating Control Module																																																												
T	2015	Aveo	Body	Keyless Entry Control Module			V																																																									
T	2015	Aveo	Body	Parking Assist Control Module																																																												
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
T	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
T	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																												
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
T	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
T	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
T	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
T	2016	Aveo	Powertrain	Chassis Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2016	Aveo	Chassis	Power Steering Control Module																																																										
T	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2016	Aveo	Body	Body Control Module Hatchback																																																										
T	2016	Aveo	Body	Body Control Module Sedan																																																										
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Aveo	Body	Instrument Cluster																																																										
T	2016	Aveo	Body	Radio																																																										
T	2016	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2016	Aveo	Body	Front Seat Heating Control Module																																																										
T	2016	Aveo	Body	Parking Assist Control Module																																																										
T	2016	Aveo	Body	Keyless Entry Control Module			V																																																							
T	2016	Aveo	Body	Frontview Camera Module																																																										
U	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																			V	V	V	V	V																			
U	2004	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																			V	V	V	V	V																			
U	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V	V																		
U	2004	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
U	2004	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																									V	V																
U	2004	ALL	Chassis	Electronic Brake Control Module																																																										
U	2004	ALL	Chassis	Electronic Brake Control Module																																																										
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																			V							
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2004	ALL	Body	Remote Function Actuation																																																										
U	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																		V								
U	2005	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																		V								
U	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V	V																		
U	2005	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
U	2005	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																									V	V																
U	2005	ALL	Chassis	Electronic Brake Control Module																																																										
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																			V							
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2005	ALL	Body	Remote Function Actuation																																																										
U	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V											V	V								
U	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V	V																		
U	2006	ALL	Powertrain	Transmission Control Module																																									V	V																
U	2006	ALL	Chassis	Electronic Brake Control Module																																																										
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																			V							
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2006	ALL	Body	Remote Function Actuation																																																										
U	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V											V	V								
U	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																								V																		
U	2007	ALL	Powertrain	Transmission Control Module																																									V	V																
U	2007	ALL	Chassis	Electronic Brake Control Module																																																										
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
U	2007	ALL	Body	Remote Function Actuation																																																											
U	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																						V									V	V									
U	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																						V									V	V									
U	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V																			
U	2008	ALL	Powertrain	Transmission Control Module																																									V	V																
U	2008	ALL	Chassis	Electronic Brake Control Module																																																										
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2008	ALL	Body	Remote Function Actuation																																																										
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																												V	V																														
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																												V																														
U	2010	Sail	Powertrain	1.4L LCU Engine Control Module																												V																														
U	2010	Sail	Powertrain	Transmission Control Module																													V	V																												
U	2010	Sail	Chassis	Electronic Brake Control Module																																																										
U	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																												
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																												V	V																													
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																												V																														
U	2011	Sail	Powertrain	1.4L LCU Engine Control Module																												V																														
U	2011	Sail	Powertrain	Transmission Control Module																													V	V																												
U	2011	Sail	Chassis	Electronic Brake Control Module																																																										
U	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																												
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																												V	V																													
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																												V																														
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																												V	V																													
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																												V																														
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																												V																														
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																												V				V																										
U	2012	Sail	Powertrain	Transmission Control Module																													V	V																												
U	2012	Sail	Chassis	Electronic Brake Control Module																																																										
U	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																												
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																												V	V																													
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																												V																														
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																												V																														
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																												V				V																										
U	2013	Sail	Powertrain	Transmission Control Module																													V	V																												
U	2013	Sail	Chassis	Electronic Brake Control Module																																																										
U	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																												
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																												V	V																													
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																												V																														
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																												V																														
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																												V				V																										
U	2014	Sail	Powertrain	Transmission Control Module																													V	V																												
U	2014	Sail	Chassis	Electronic Brake Control Module																																																										
U	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																												
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																												V	V																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																												V																												
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
U	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																V	V																							
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																												V																												
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																												V				V																								
U	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																V	V																							
U	2015	Sail	Powertrain	Transmission Control Module																													V	V																										
U	2015	Sail	Chassis	Electronic Brake Control Module																																																							
U	2015	Sail	Chassis	Electronic Brake Control Module																																																							
U	2015	Sail	Chassis	Power Steering Control Module																																																						
U	2015	Sail	Body	Body Control Module																																		V																					
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																								
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
U	2015	Sail	Body	Radio/HVAC Control																																																						
U	2015	Sail	Body	HVAC Control Module																											V																												
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																												V	V																										
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																												V																												
U	2016	Sail	Powertrain	1.2L LMU Transmission Control Module																													V	V																									
U	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																							
U	2016	Sail	Powertrain	1.3L LDV Transmission Control Module																													V	V																									
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																												V																												
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																												V				V																								
U	2016	Sail	Powertrain	1.4L LCU Transmission Control Module																													V	V																									
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																V	V																							
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																V	V																							
U	2016	Sail	Powertrain	1.5L L2B Transmission Control Module						V																																																	
U	2016	Sail	Chassis	Electronic Brake Control Module																																																							
U	2016	Sail	Chassis	Electronic Brake Control Module																																																							
U	2016	Sail	Chassis	Power Steering Control Module																																																						
U	2016	Sail	Body	Body Control Module																																		V																					
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																															V																								
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
U	2016	Sail	Body	Radio/HVAC Control																																																						
U	2016	Sail	Body	Radio																																																						
U	2016	Sail	Body	HVAC Control Module																											V																												
V	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V	V														
V	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																						V									V						
V	2004	ALL	Powertrain	Transmission Control Module 4 Speed																																									V	V											
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																					
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																					
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																					
V	2004	ALL	Body	ISU																																																					
V	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V	V													
V	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																						V									V						
V	2005	ALL	Powertrain	Transmission Control Module 4 Speed																																									V	V											
V	2005	ALL	Chassis	Electronic Brake Control Module																																																					
V	2005	ALL	Body	Supplemental Inflatable Restraint																																																					
V	2005	ALL	Body	ISU																																																					
V	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																							V	V													
V	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																						V									V						

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
V	2006	ALL	Powertrain	Transmission Control Module 4 Speed																																										V	V														
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																								
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																								
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																V								
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2006	ALL	Body	ISU																																																								
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																						V																		
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector Control Module																																																								
V	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																							V																	
V	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																				V	V	V	V
V	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																						V																		
V	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																						V																		
V	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																										V	V													
V	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
V	2007	ALL	Chassis	Electronic Brake Control Module																																																								
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																V								
V	2007	ALL	Body	ISU																																																								
V	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																						V																		
V	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																						V																		
V	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
V	2008	ALL	Chassis	Electronic Brake Control Module																																																								
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																V								
V	2008	ALL	Body	ISU																																																								
V	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																						V																		
V	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																						V																		
V	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
V	2009	ALL	Chassis	Electronic Brake Control Module																																																								
V	2009	ALL	Body	ISU																																																								
V	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																			V	V	V	V	V
V	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																						V																		
V	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																						V																		
V	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
V	2010	ALL	Chassis	Electronic Brake Control Module																																																								
V	2010	ALL	Body	ISU																																																								
V	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																			V	V	V	V	V
V	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																						V																		
V	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																						V																		
V	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
V	2011	ALL	Chassis	Electronic Brake Control Module																																																								
V	2011	ALL	Body	ISU																																																								
W	2004	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																								
W	2004	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																								
W	2004	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																								
W	2004	ALL	Powertrain	Transmission Control Module																																																								
W	2004	ALL	Body	Body Control Module																																																								
W	2004	ALL	Body	Digital Radio Receiver																																																								
W	2004	ALL	Body	Driver Information Center																																																								
W	2004	ALL	Body	Heating and Air Conditioning																																																								
W	2004	ALL	Body	Instrument Panel Cluster																																																								
W	2004	ALL	Body	Personalization																																																								
W	2004	ALL	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
W	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																										
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																										
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																										
W	2005	ALL	Powertrain	Transmission Control Module																																																										
W	2005	ALL	Body	Body Control Module																																																										
W	2005	ALL	Body	Digital Radio Receiver																																																										
W	2005	ALL	Body	Driver Information Center																																																										
W	2005	ALL	Body	Heating and Air Conditioning																																																										
W	2005	ALL	Body	Instrument Panel Cluster																																																										
W	2005	ALL	Body	Personalization																																																										
W	2005	ALL	Body	Radio																																																										
W	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																										
W	2006	ALL	Powertrain	Transmission Control Module																																																										
W	2006	ALL	Chassis	Anti-lock Brake System																																																										
W	2006	ALL	Body	Digital Radio Receiver																																																										
W	2006	ALL	Body	Radio																																																										
W	2006	ALL	Body	Instrument Panel Cluster																																																										
W	2006	ALL	Body	Seat																																																										
W	2006	ALL	Body	Theft Deterrent Module																																																										
W	2006	ALL	Body	Body Control Module																																																										
W	2006	ALL	Body	HVAC C67 Single																																																										
W	2006	ALL	Body	HVAC CJ3 Dual																																																										
W	2006	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2006	ALL	Body	Passenger Presence System																																																										
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																										
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module																																																										
W	2007	ALL	Powertrain	Transmission Control Module																																																										
W	2007	ALL	Chassis	Electronic Brake Control Module																																																										
W	2007	ALL	Body	Body Control Module																																																										
W	2007	ALL	Body	Digital Radio Receiver																																																										
W	2007	ALL	Body	Heated Seat Module																																																										
W	2007	ALL	Body	HVAC C67 Single																																																										
W	2007	ALL	Body	HVAC CJ3 Dual																																																										
W	2007	ALL	Body	Instrument Panel Cluster																																																										
W	2007	ALL	Body	Passenger Presence System																																																										
W	2007	ALL	Body	Radio																																																										
W	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2007	ALL	Body	Theft Deterrent Module																																																										
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module																																																										
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																										
W	2008	ALL	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
W	2008	ALL	Chassis	Electronic Brake Control Module																																																											
W	2008	ALL	Body	Body Control Module																																																												
W	2008	ALL	Body	Digital Radio Receiver																																																												
W	2008	ALL	Body	Heated Seat Module																																																												
W	2008	ALL	Body	HVAC C67 Single																																																												
W	2008	ALL	Body	HVAC CJ3 Dual																																																												
W	2008	ALL	Body	Instrument Panel Cluster																																																												
W	2008	ALL	Body	Passenger Presence System																																																												
W	2008	ALL	Body	Radio																																																												
W	2008	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2008	ALL	Body	Theft Deterrent Module																																																												
W	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																												
W	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																												
W	2009	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																												
W	2009	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																												
W	2009	ALL	Powertrain	Transmission Control Module																																																												
W	2009	ALL	Chassis	Electronic Brake Control Module																																																												
W	2009	ALL	Body	Body Control Module																																																												
W	2009	ALL	Body	Digital Radio Receiver																																																												
W	2009	ALL	Body	Heated Seat Module																																																												
W	2009	ALL	Body	HVAC C67 Single																																																												
W	2009	ALL	Body	HVAC CJ3 Dual																																																												
W	2009	ALL	Body	Instrument Panel Cluster																																																												
W	2009	ALL	Body	Passenger Presence System																																																												
W	2009	ALL	Body	Radio																																																												
W	2009	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2009	ALL	Body	Theft Deterrent Module																																																												
W	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																												
W	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																												
W	2010	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																												
W	2010	ALL	Powertrain	Transmission Control Module																																																												
W	2010	ALL	Chassis	Electronic Brake Control Module																																																												
W	2010	ALL	Body	Body Control Module																																																												
W	2010	ALL	Body	Digital Radio Receiver																																																												
W	2010	ALL	Body	Heated Seat Module																																																												
W	2010	ALL	Body	HVAC C67 Single																																																												
W	2010	ALL	Body	HVAC CJ3 Dual																																																												
W	2010	ALL	Body	Instrument Panel Cluster																																																												
W	2010	ALL	Body	Passenger Presence System																																																												
W	2010	ALL	Body	Radio																																																												
W	2010	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2010	ALL	Body	Theft Deterrent Module																																																												
W	2011	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																												
W	2011	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																												
W	2011	ALL	Powertrain	Transmission Control Module																																																												
W	2011	ALL	Chassis	Electronic Brake Control Module																																																												
W	2011	ALL	Body	Body Control Module																																																												
W	2011	ALL	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
W	2011	ALL	Body	Heated Seat Module																																																											
W	2011	ALL	Body	HVAC C67 Single																																																												
W	2011	ALL	Body	HVAC CJ3 Dual																																																												
W	2011	ALL	Body	Instrument Panel Cluster																																																												
W	2011	ALL	Body	Passenger Presence System																																																												
W	2011	ALL	Body	Radio																																																												
W	2011	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2011	ALL	Body	Theft Deterrent Module																																																												
W	2012	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																												
W	2012	ALL	Powertrain	Transmission Control Module																																																												
W	2012	ALL	Powertrain	Fuel Pump Control Module																																																												
W	2012	ALL	Chassis	Electronic Brake Control Module																																																												
W	2012	ALL	Body	Body Control Module																																																												
W	2012	ALL	Body	Digital Radio Receiver																																																												
W	2012	ALL	Body	Heated Seat Module																																																												
W	2012	ALL	Body	HVAC C67 Single																																																												
W	2012	ALL	Body	HVAC CJ3 Dual																																																												
W	2012	ALL	Body	Instrument Panel Cluster																																																												
W	2012	ALL	Body	Passenger Presence System																																																												
W	2012	ALL	Body	Radio																																																												
W	2012	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2012	ALL	Body	Theft Deterrent Module																																																												
W	2013	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																												
W	2013	ALL	Powertrain	Transmission Control Module																																																												
W	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
W	2013	ALL	Chassis	Electronic Brake Control Module																																																												
W	2013	ALL	Body	Body Control Module																																																												
W	2013	ALL	Body	Digital Radio Receiver																																																												
W	2013	ALL	Body	Heated Seat Module																																																												
W	2013	ALL	Body	HVAC C67 Single																																																												
W	2013	ALL	Body	HVAC CJ3 Dual																																																												
W	2013	ALL	Body	Instrument Panel Cluster																																																												
W	2013	ALL	Body	Passenger Presence System																																																												
W	2013	ALL	Body	Radio																																																												
W	2013	ALL	Body	Remote Control Door Lock Receiver																																																												
W	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
W	2013	ALL	Body	Theft Deterrent Module																																																												
W	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
W	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
W	2014	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																												
W	2014	Impala	Chassis	Electronic Brake Control Module																																																												
W	2014	Impala	Body	Body Control Module																																																												
W	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
W	2014	Impala	Body	Passenger Presence Module																																																												
W	2014	Impala	Body	Instrument Cluster																																																												
W	2014	Impala	Body	Radio																																																												
W	2014	Impala	Body	Digital Radio Receiver Control Module																																																												
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																												
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
W	2014	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
W	2014	Impala	Body	HVAC Manual Control Single Zone (C67)																																																								
W	2014	Impala	Body	Front Seat Heating Control Module																																																								
W	2014	Impala	Body	Remote Control Door Lock Receiver																																																								
W	2014	Impala	Body	Theft Deterrent Module																																																								
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																								
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																								
W	2014	Lumina	Powertrain	(2) 6.0L L77 Transmission Control Module																																																								
W	2014	Lumina	Powertrain	Fuel Injector Control Module																																																								
W	2014	Lumina	Powertrain	Chassis Control Module																																																								
W	2014	Lumina	Chassis	Electronic Brake Control Module																																																								
W	2014	Lumina	Chassis	Parking Brake Control Module																																																								
W	2014	Lumina	Chassis	Power Steering Control Module																																																								
W	2014	Lumina	Chassis	Steering Wheel Angle Sensor Module																																																								
W	2014	Lumina	Chassis	Suspension Control Module																							V	V																																
W	2014	Lumina	Body	Body Control Module Coupe																																																								
W	2014	Lumina	Body	Body Control Module Sedan																																																								
W	2014	Lumina	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
W	2014	Lumina	Body	Instrument Cluster																																																								
W	2014	Lumina	Body	Head-Up Display Module																																																								
W	2014	Lumina	Body	Radio Control																																																								
W	2014	Lumina	Body	HVAC Control																																																								
W	2014	Lumina	Body	Headlamp Control Module																																																								
W	2014	Lumina	Body	Trailer Interface Control Module																																																								
W	2014	Lumina	Body	Radio																																																								
W	2014	Lumina	Body	HVAC Control Module																																																								
W	2014	Lumina	Body	Keyless Entry Control Module																																																								
W	2014	Lumina	Body	Right Side Object Detection Control Module																																																								
W	2014	Lumina	Body	Left Side Object Detection Control Module																																																								
W	2014	Lumina	Body	Parking Assist Control Module																					V																																			
W	2014	Lumina	Body	Frontview Camera Module																						V																																		
W	2014	Lumina	Body	Steering Column Lock Control Module																																																								
W	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
W	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
W	2015	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																								
W	2015	Impala	Chassis	Electronic Brake Control Module																																																								
W	2015	Impala	Body	Body Control Module																																																								
W	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
W	2015	Impala	Body	Passenger Presence Module																																																								
W	2015	Impala	Body	Instrument Cluster																																																								
W	2015	Impala	Body	Radio																																																								
W	2015	Impala	Body	Digital Radio Receiver Control Module																																																								
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 9																																																								
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 10																																																								
W	2015	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
W	2015	Impala	Body	HVAC Manual Control Single Zone (C67)																																																								
W	2015	Impala	Body	Front Seat Heating Control Module																																																								
W	2015	Impala	Body	Remote Control Door Lock Receiver																																																								
W	2015	Impala	Body	Theft Deterrent Module																																																								
W	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
W	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
W	2016	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																											
W	2016	Impala	Chassis	Electronic Brake Control Module																																																												
W	2016	Impala	Body	Body Control Module																																																											
W	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
W	2016	Impala	Body	Passenger Presence Module																																																												
W	2016	Impala	Body	Instrument Cluster																																																												
W	2016	Impala	Body	Radio																																																												
W	2016	Impala	Body	Digital Radio Receiver Control Module																																																												
W	2016	Impala	Body	Telematics Communication Interface Control Module																																																												
W	2016	Impala	Body	HVAC Manual Control Dual Zone (CJ2)																																																												
W	2016	Impala	Body	HVAC Manual Control Single Zone (C67)																																																												
W	2016	Impala	Body	Front Seat Heating Control Module																																																												
W	2016	Impala	Body	Remote Control Door Lock Receiver																																																												
W	2016	Impala	Body	Theft Deterrent Module																																																												
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Auto																																																												
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Manual																																																												
Y	2004	ALL	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																												
Y	2004	ALL	Powertrain	Transmission Control Module																																																												
Y	2004	ALL	Chassis	RTD																																																												
Y	2004	ALL	Body	Body Control Module																																																												
Y	2004	ALL	Body	Heating and Air Conditioning																																																												
Y	2004	ALL	Body	Instrument Panel Cluster																																																												
Y	2004	ALL	Body	Left Door Control Module																																																												
Y	2004	ALL	Body	Radio																																																												
Y	2004	ALL	Body	Remote Function Actuation																																																												
Y	2004	ALL	Body	Right Door Control Module																																																												
Y	2004	ALL	Body	Seat Control Module																																																												
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2005	ALL	Powertrain	Engine Control Module																																																												
Y	2005	ALL	Powertrain	Transmission Control Module																																																												
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2005	ALL	Chassis	Electronic Suspension Control																																																												
Y	2005	ALL	Chassis	Steering Wheel and Column																																																												
Y	2005	ALL	Body	Amplifier																																																											
Y	2005	ALL	Body	Body Control Module																																																											
Y	2005	ALL	Body	Digital Radio Receiver																																																												
Y	2005	ALL	Body	Driver Door Module																																																											
Y	2005	ALL	Body	Driver Door Switch																																																											
Y	2005	ALL	Body	Driver Position Module																																																											
Y	2005	ALL	Body	Folding Top Module																																																											
Y	2005	ALL	Body	Head Up Display																																																											
Y	2005	ALL	Body	HVAC Control Module																																																											
Y	2005	ALL	Body	Instrument Panel Cluster																																																											
Y	2005	ALL	Body	Navigation Radio																																																											
Y	2005	ALL	Body	Passenger Door Module																																																											
Y	2005	ALL	Body	Radio																																																											
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																											
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2006	ALL	Powertrain	Engine Control Module																																																											
Y	2006	ALL	Powertrain	Exhaust Flow Control Module																																																											
Y	2006	ALL	Powertrain	Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Y	2006	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2006	ALL	Chassis	Electronic Suspension Control																																																												
Y	2006	ALL	Chassis	Steering Wheel and Column																																																												
Y	2006	ALL	Body	Body Control Module																																																												
Y	2006	ALL	Body	CD Changer																																																												
Y	2006	ALL	Body	Digital Radio Receiver																																																												
Y	2006	ALL	Body	Driver Door Module																																																												
Y	2006	ALL	Body	Driver Door Switch																																																												
Y	2006	ALL	Body	Driver Position Module																																																												
Y	2006	ALL	Body	Folding Top Module																																																												
Y	2006	ALL	Body	Head Up Display																																																												
Y	2006	ALL	Body	HVAC Control Module																																																												
Y	2006	ALL	Body	Instrument Panel Cluster																																																												
Y	2006	ALL	Body	Navigation Radio																																																												
Y	2006	ALL	Body	Passenger Door Module																																																												
Y	2006	ALL	Body	Radio																																																												
Y	2006	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2007	ALL	Powertrain	Engine Control Module																																																												
Y	2007	ALL	Powertrain	Exhaust Flow Control Module																																																												
Y	2007	ALL	Powertrain	Transmission Control Module																																																												
Y	2007	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2007	ALL	Chassis	Electronic Suspension Control																																																												
Y	2007	ALL	Body	Body Control Module																																																												
Y	2007	ALL	Body	CD Changer																																																												
Y	2007	ALL	Body	Digital Radio Receiver																																																												
Y	2007	ALL	Body	Driver Door Module																																																												
Y	2007	ALL	Body	Driver Door Switch																																																												
Y	2007	ALL	Body	Driver Position Module																																																												
Y	2007	ALL	Body	Folding Top Module																																																												
Y	2007	ALL	Body	Head Up Display																																																												
Y	2007	ALL	Body	HVAC Control Module																																																												
Y	2007	ALL	Body	Instrument Panel Cluster																																																												
Y	2007	ALL	Body	Navigation Radio																																																												
Y	2007	ALL	Body	Passenger Door Module																																																												
Y	2007	ALL	Body	Radio																																																												
Y	2007	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2007	ALL	Body	Steering Column Lock Module																																																												
Y	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2008	ALL	Powertrain	Engine Control Module																																																												
Y	2008	ALL	Powertrain	Exhaust Flow Control Module																																																												
Y	2008	ALL	Powertrain	Transmission Control Module																																																												
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2008	ALL	Chassis	Electronic Suspension Control																																																												
Y	2008	ALL	Body	Body Control Module																																																												
Y	2008	ALL	Body	CD Changer																																																												
Y	2008	ALL	Body	Digital Radio Receiver																																																												
Y	2008	ALL	Body	Driver Door Module																																																												
Y	2008	ALL	Body	Driver Door Switch																																																												
Y	2008	ALL	Body	Driver Position Module																																																												
Y	2008	ALL	Body	Folding Top Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Y	2008	ALL	Body	Head Up Display																																																											
Y	2008	ALL	Body	HVAC Control Module																																																											
Y	2008	ALL	Body	Instrument Panel Cluster																																																											
Y	2008	ALL	Body	Navigation Radio																																																											
Y	2008	ALL	Body	Passenger Door Module																																																											
Y	2008	ALL	Body	Radio																																																											
Y	2008	ALL	Body	Personal Audio Link Module																																																											
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																											
Y	2008	ALL	Body	Steering Column Lock Module																																																											
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																											
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																											
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																											
Y	2009	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2009	ALL	Chassis	Electronic Suspension Control																																																											
Y	2009	ALL	Body	Body Control Module																																																											
Y	2009	ALL	Body	CD Changer																																																											
Y	2009	ALL	Body	Digital Radio Receiver																																																											
Y	2009	ALL	Body	Driver Door Module																																																											
Y	2009	ALL	Body	Driver Door Switch																																																											
Y	2009	ALL	Body	Driver Position Module																																																											
Y	2009	ALL	Body	Folding Top Module																																																											
Y	2009	ALL	Body	Head Up Display																																																											
Y	2009	ALL	Body	HVAC Control Module																																																											
Y	2009	ALL	Body	Instrument Panel Cluster																																																											
Y	2009	ALL	Body	Navigation Radio																																																											
Y	2009	ALL	Body	Passenger Door Module																																																											
Y	2009	ALL	Body	Radio																																																											
Y	2009	ALL	Body	Personal Audio Link Module																																																											
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																																											
Y	2009	ALL	Body	Steering Column Lock Module																																																											
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																											
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																											
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																											
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																											
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																											
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																											
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																											
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																											
Y	2010	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2010	ALL	Chassis	Electronic Suspension Control																																																											
Y	2010	ALL	Body	Body Control Module																																																											
Y	2010	ALL	Body	CD Changer																																																											
Y	2010	ALL	Body	Digital Radio Receiver																																																											
Y	2010	ALL	Body	Driver Door Module																																																											
Y	2010	ALL	Body	Driver Door Switch																																																											
Y	2010	ALL	Body	Driver Position Module																																																											
Y	2010	ALL	Body	Folding Top Module																																																											
Y	2010	ALL	Body	Head Up Display																																																											
Y	2010	ALL	Body	HVAC Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Y	2010	ALL	Body	Instrument Panel Cluster																																																											
Y	2010	ALL	Body	Navigation Radio																																																												
Y	2010	ALL	Body	Passenger Door Module																																																												
Y	2010	ALL	Body	Radio																																																												
Y	2010	ALL	Body	Personal Audio Link Module																																																												
Y	2010	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2010	ALL	Body	Steering Column Lock Module																																																												
Y	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																												
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																												
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																												
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																												
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																												
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																												
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																												
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																												
Y	2011	ALL	Chassis	Electronic Brake Control Module																																																													
Y	2011	ALL	Chassis	Electronic Suspension Control																																																													
Y	2011	ALL	Body	Body Control Module																																																												
Y	2011	ALL	Body	CD Changer																																																												
Y	2011	ALL	Body	Digital Radio Receiver																																																												
Y	2011	ALL	Body	Driver Door Module																																																												
Y	2011	ALL	Body	Driver Door Switch																																																												
Y	2011	ALL	Body	Driver Position Module																																																												
Y	2011	ALL	Body	Folding Top Module																																																												
Y	2011	ALL	Body	Head Up Display																																																												
Y	2011	ALL	Body	HVAC Control Module																																																												
Y	2011	ALL	Body	Instrument Panel Cluster																																																												
Y	2011	ALL	Body	Navigation Radio																																																												
Y	2011	ALL	Body	Passenger Door Module																																																												
Y	2011	ALL	Body	Radio																																																												
Y	2011	ALL	Body	Personal Audio Link Module																																																												
Y	2011	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2011	ALL	Body	Steering Column Lock Module																																																												
Y	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																												
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																												
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																												
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																												
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																												
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																												
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																												
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																												
Y	2012	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2012	ALL	Chassis	Electronic Suspension Control																																																												
Y	2012	ALL	Body	Body Control Module																																																												
Y	2012	ALL	Body	CD Changer																																																												
Y	2012	ALL	Body	Digital Radio Receiver																																																												
Y	2012	ALL	Body	Driver Door Module																																																												
Y	2012	ALL	Body	Driver Door Switch																																																												
Y	2012	ALL	Body	Driver Position Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Y	2012	ALL	Body	Folding Top Module																																																											
Y	2012	ALL	Body	Head Up Display																																																											
Y	2012	ALL	Body	HVAC Control Module																																																											
Y	2012	ALL	Body	Instrument Panel Cluster																																																											
Y	2012	ALL	Body	Navigation Radio																																																											
Y	2012	ALL	Body	Passenger Door Module																																																											
Y	2012	ALL	Body	Radio																																																											
Y	2012	ALL	Body	Personal Audio Link Module																																																											
Y	2012	ALL	Body	Remote Control Door Lock Receiver																																																											
Y	2012	ALL	Body	Steering Column Lock Module																																																											
Y	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																											
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																											
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																											
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																											
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																											
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																											
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																											
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																											
Y	2013	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2013	ALL	Chassis	Electronic Suspension Control																																																											
Y	2013	ALL	Body	Body Control Module																																																											
Y	2013	ALL	Body	CD Changer																																																											
Y	2013	ALL	Body	Digital Radio Receiver																																																											
Y	2013	ALL	Body	Driver Door Module																																																											
Y	2013	ALL	Body	Driver Door Switch																																																											
Y	2013	ALL	Body	Driver Position Module																																																											
Y	2013	ALL	Body	Folding Top Module																																																											
Y	2013	ALL	Body	Head Up Display																																																											
Y	2013	ALL	Body	HVAC Control Module																																																											
Y	2013	ALL	Body	Instrument Panel Cluster																																																											
Y	2013	ALL	Body	Navigation Radio																																																											
Y	2013	ALL	Body	Passenger Door Module																																																											
Y	2013	ALL	Body	Radio																																																											
Y	2013	ALL	Body	Personal Audio Link Module																																																											
Y	2013	ALL	Body	Remote Control Door Lock Receiver																																																											
Y	2013	ALL	Body	Steering Column Lock Module																																																											
Y	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																											
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																											
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																											
Y	2014	Corvette	Powertrain	Chassis Control Module																																																											
Y	2014	Corvette	Chassis	Electronic Brake Control Module																																																											
Y	2014	Corvette	Chassis	Parking Brake Control Module																																																											
Y	2014	Corvette	Chassis	Power Steering Control Module																																																											
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																											
Y	2014	Corvette	Chassis	Suspension Control Module																																																											
Y	2014	Corvette	Body	Body Control Module Convertible																																																											
Y	2014	Corvette	Body	Body Control Module Coupe																																																											
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
Y	2014	Corvette	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Y	2014	Corvette	Body	Instrument Cluster																																																											
Y	2014	Corvette	Body	Radio/HVAC Control																																																												
Y	2014	Corvette	Body	Inside Rearview Mirror																																																												
Y	2014	Corvette	Body	Radio																																																												
Y	2014	Corvette	Body	Amplifier																																																												
Y	2014	Corvette	Body	Human Machine Interface Control Module																																																												
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																												
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																												
Y	2014	Corvette	Body	HVAC Control Module																																																												
Y	2014	Corvette	Body	Seat Memory Control Module - Passenger																																																												
Y	2014	Corvette	Body	Seat Memory Control Module - Driver																									V																																			
Y	2014	Corvette	Body	Folding Top Control Module																	V	V																																									
Y	2014	Corvette	Body	Keyless Entry Control Module																																																												
Y	2014	Corvette	Body	Steering Column Lock Control Module																																																												
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																												
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																												
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																												
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Automatic Transmission																																																												
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Manual Transmission																																																												
Y	2015	Corvette	Powertrain	6.2L LT4 Transmission Control Module																																																												
Y	2015	Corvette	Powertrain	Chassis Control Module																																																												
Y	2015	Corvette	Chassis	Electronic Brake Control Module																																																												
Y	2015	Corvette	Chassis	Parking Brake Control Module																																																												
Y	2015	Corvette	Chassis	Power Steering Control Module																																																												
Y	2015	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																												
Y	2015	Corvette	Chassis	Suspension Control Module																																																												
Y	2015	Corvette	Body	Body Control Module Convertible																																																												
Y	2015	Corvette	Body	Body Control Module Coupe																																																												
Y	2015	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
Y	2015	Corvette	Body	Passenger Presence Module																																																												
Y	2015	Corvette	Body	Instrument Cluster																																																												
Y	2015	Corvette	Body	Radio/HVAC Control																																																												
Y	2015	Corvette	Body	Vehicle Performance Data Recorder																																																												
Y	2015	Corvette	Body	Inside Rearview Mirror																																																												
Y	2015	Corvette	Body	Radio																																																											
Y	2015	Corvette	Body	Amplifier																																																											
Y	2015	Corvette	Body	Human Machine Interface Control Module																																																												
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																												
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																												
Y	2015	Corvette	Body	HVAC Control Module																																																												
Y	2015	Corvette	Body	Seat Memory Control Module - Passenger																																																												
Y	2015	Corvette	Body	Seat Memory Control Module - Driver																																																												
Y	2015	Corvette	Body	Folding Top Control Module																	V	V																																									
Y	2015	Corvette	Body	Keyless Entry Control Module																																																												
Y	2015	Corvette	Body	Steering Column Lock Control Module																																																												
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																												
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																												
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Automatic Transmission																																																												
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Manual Transmission																																																												
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Y	2016	Corvette	Powertrain	Rear Differential Clutch Control Module																																																											
Y	2016	Corvette	Chassis	Electronic Brake Control Module																																																												
Y	2016	Corvette	Chassis	Parking Brake Control Module																																																												
Y	2016	Corvette	Chassis	Power Steering Control Module																																																												
Y	2016	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																												
Y	2016	Corvette	Chassis	Suspension Control Module																																																												
Y	2016	Corvette	Body	Body Control Module																																																												
Y	2016	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
Y	2016	Corvette	Body	Passenger Presence Module																																																												
Y	2016	Corvette	Body	Instrument Cluster																																																												
Y	2016	Corvette	Body	Radio/HVAC Control																																																												
Y	2016	Corvette	Body	Vehicle Performance Data Recorder																																																												
Y	2016	Corvette	Body	Video Processing Control Module																																																												
Y	2016	Corvette	Body	Inside Rearview Mirror																																																												
Y	2016	Corvette	Body	Radio																																																												
Y	2016	Corvette	Body	Amplifier																																																												
Y	2016	Corvette	Body	Human Machine Interface Control Module																																																												
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																												
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																												
Y	2016	Corvette	Body	HVAC Control Module																																																												
Y	2016	Corvette	Body	Liftgate Control Module																																																												
Y	2016	Corvette	Body	Seat Memory Control Module - Passenger																																																												
Y	2016	Corvette	Body	Seat Memory Control Module - Driver																																																												
Y	2016	Corvette	Body	Folding Top Control Module																	V	V																																									
Y	2016	Corvette	Body	Keyless Entry Control Module																																																												
Y	2016	Corvette	Body	Steering Column Lock Control Module																																																												
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																												
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																												
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																												
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																												
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																												
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																												
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																												
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																												
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																												
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																												
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																												
Y	2016	Cruze	Chassis	Electronic Brake Control Module																																																												
Y	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																												
Y	2016	Cruze	Chassis	Power Steering Control Module																																																												
Y	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
Y	2016	Cruze	Body	Body Control Module																																																												
Y	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
Y	2016	Cruze	Body	Passenger Presence Module																																																												
Y	2016	Cruze	Body	Instrument Cluster																																																												
Y	2016	Cruze	Body	Radio Controls																																																												
Y	2016	Cruze	Body	HVAC Controls																																																												
Y	2016	Cruze	Body	Trailer Interface Control Module																																																												
Y	2016	Cruze	Body	Radio Base (IO3 IO7)																																																												
Y	2016	Cruze	Body	Radio (IOA)																																																												
Y	2016	Cruze	Body	Radio (IOB)																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Y	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																											
Y	2016	Cruze	Body	Amplifier																																																												
Y	2016	Cruze	Body	Multimedia Player Interface Module																																																												
Y	2016	Cruze	Body	Human Machine Interface Control Module																																																												
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																												
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
Y	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
Y	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																												
Y	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																												
Y	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																												
Y	2016	Cruze	Body	Keyless Entry Control Module																																																												
Y	2016	Cruze	Body	Right Side Object Detection Control Module																																																												
Y	2016	Cruze	Body	Left Side Object Detection Control Module																																																												
Y	2016	Cruze	Body	Parking Assist Control Module					V																																																							
Y	2016	Cruze	Body	Frontview Camera Module																																																												
Y	2016	Cruze	Body	Steering Column Lock Control Module																																																												
Y	2016	Cruze	Body	Long Range Radar Sensor Module																																																												
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																												
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Transmission Control Module																																																												
Z	2004	ALL	Chassis	Electronic Brake Control Module																																																												
Z	2004	ALL	Chassis	Power Steering Control Module																																																												
Z	2004	ALL	Body	Body Control Module																																																												
Z	2004	ALL	Body	Digital Radio Receiver																																																												
Z	2004	ALL	Body	HVAC Control Module																																																												
Z	2004	ALL	Body	Instrument Panel Cluster																																																												
Z	2004	ALL	Body	Radio																																																												
Z	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
Z	2004	ALL	Body	Theft Deterrent Module																																																												
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
Z	2005	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																												
Z	2005	ALL	Chassis	Electronic Brake Control Module																																																												
Z	2005	ALL	Chassis	Power Steering Control Module																																																												
Z	2005	ALL	Body	Body Control Module																																																												
Z	2005	ALL	Body	Digital Radio Receiver																																																												
Z	2005	ALL	Body	HVAC Control Module																																																												
Z	2005	ALL	Body	Instrument Panel Cluster																																																												
Z	2005	ALL	Body	Radio																																																												
Z	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
Z	2005	ALL	Body	Theft Deterrent Module																																																												
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																												
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																												
Z	2006	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																												
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																												
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																												
Z	2006	ALL	Chassis	Electronic Brake Control Module																																																												
Z	2006	ALL	Chassis	Power Steering Control Module																																																												
Z	2006	ALL	Body	Body Control Module																																																												
Z	2006	ALL	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Z	2006	ALL	Body	HVAC Control Module																																																											
Z	2006	ALL	Body	Instrument Panel Cluster																																																												
Z	2006	ALL	Body	Radio																																																											
Z	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2006	ALL	Body	Theft Deterrent Module																																																											
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																											
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																											
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																											
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																											
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																											
Z	2007	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2007	ALL	Chassis	Power Steering Control Module																																																											
Z	2007	ALL	Body	Body Control Module																																																										
Z	2007	ALL	Body	Digital Radio Receiver																																																										
Z	2007	ALL	Body	Disc Player and Video Display																																																										
Z	2007	ALL	Body	HVAC Control Module																																																										
Z	2007	ALL	Body	Instrument Panel Cluster																																																										
Z	2007	ALL	Body	Radio																																																										
Z	2007	ALL	Body	Remote Control Door Lock Receiver																																																										
Z	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2007	ALL	Body	Theft Deterrent Module																																																										
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																										
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																										
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																										
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																										
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
Z	2008	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2008	ALL	Chassis	Power Steering Control Module																																																										
Z	2008	ALL	Body	Body Control Module Classic																																																										
Z	2008	ALL	Body	Body Control Module Malibu																																																										
Z	2008	ALL	Body	Digital Radio Receiver																																																										
Z	2008	ALL	Body	Disc Player and Video Display																																																										
Z	2008	ALL	Body	HVAC Control Module Classic																																																										
Z	2008	ALL	Body	HVAC Control Module Malibu																																																										
Z	2008	ALL	Body	Instrument Panel Cluster Classic																																																										
Z	2008	ALL	Body	Instrument Panel Cluster Malibu																																																										
Z	2008	ALL	Body	Radio																																																										
Z	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
Z	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2008	ALL	Body	Theft Deterrent Module																																																										
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																										
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																										
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																										
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump																																																										
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump																																																										
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Without Tap Shift																																																											
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																												
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																												
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
Z	2009	ALL	Chassis	Electronic Brake Control Module																																																												
Z	2009	ALL	Chassis	Power Steering Control Module																																																												
Z	2009	ALL	Body	Body Control Module																																																												
Z	2009	ALL	Body	Digital Radio Receiver																																																												
Z	2009	ALL	Body	Disc Player and Video Display																																																												
Z	2009	ALL	Body	HVAC Control Module																																																												
Z	2009	ALL	Body	Instrument Panel Cluster																																																												
Z	2009	ALL	Body	Personal Audio Link Module																																																												
Z	2009	ALL	Body	Radio																																																												
Z	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
Z	2009	ALL	Body	Theft Deterrent Module																																																												
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																												
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																												
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																												
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Engine Control Module																																																												
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 6 Speed																																																												
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 4 Speed																																																												
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																												
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																												
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																												
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																												
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
Z	2010	ALL	Chassis	Electronic Brake Control Module																																																												
Z	2010	ALL	Chassis	Power Steering Control Module																																																												
Z	2010	ALL	Body	Body Control Module																																																												
Z	2010	ALL	Body	Digital Radio Receiver																																																												
Z	2010	ALL	Body	HVAC Control Module																																																												
Z	2010	ALL	Body	Instrument Panel Cluster																																																												
Z	2010	ALL	Body	Personal Audio Link Module																																																												
Z	2010	ALL	Body	Radio																																																												
Z	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
Z	2010	ALL	Body	Theft Deterrent Module																																																												
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																												
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																												
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																												
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																												
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
Z	2011	ALL	Chassis	Electronic Brake Control Module																																																												
Z	2011	ALL	Chassis	Power Steering Control Module																																																												
Z	2011	ALL	Body	Body Control Module																																																												
Z	2011	ALL	Body	Digital Radio Receiver																																																												
Z	2011	ALL	Body	HVAC Control Module																																																												
Z	2011	ALL	Body	Instrument Panel Cluster																																																												
Z	2011	ALL	Body	Personal Audio Link Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Z	2011	ALL	Body	Radio																																																											
Z	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2011	ALL	Body	Theft Deterrent Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Engine Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Transmission Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Chassis	Electronic Brake Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Chassis	Power Steering Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Body	Body Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Body	Digital Radio Receiver																																																											
Z	2012	Malibu (Seventh Gen)	Body	HVAC Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Body	Instrument Panel Cluster																																																											
Z	2012	Malibu (Seventh Gen)	Body	Personal Audio Link Module																																																											
Z	2012	Malibu (Seventh Gen)	Body	Radio																																																											
Z	2012	Malibu (Seventh Gen)	Body	Supplemental Inflatable Restraint																																																											
Z	2012	Malibu (Seventh Gen)	Body	Theft Deterrent Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Fuel Pump Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Fuel Pump Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	Rear Differential Clutch Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Electronic Brake Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Parking Brake Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Power Steering Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Steering Wheel Angle Sensor Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Suspension Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																											
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																											
Z	2012	Malibu (Eighth Gen)	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Z	2012	Malibu (Eighth Gen)	Body	Instrument Cluster																																																											
Z	2012	Malibu (Eighth Gen)	Body	Head-Up Display Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Headlamp Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Radio																																																												
Z	2012	Malibu (Eighth Gen)	Body	Digital Radio Receiver Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Multimedia Player Interface Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Mobile Telephone Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Dual (CJ2)																											V																																	
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Single (C68)																											V																																	
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Manual Single (C67)																											V																																	
Z	2012	Malibu (Eighth Gen)	Body	Rear Seat Heating Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Keyless Entry Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Right Side Object Detection Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Left Side Object Detection Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Parking Assist Control Module																																																												
Z	2012	Malibu (Eighth Gen)	Body	Vehicle Direction Camera Control Module																					V																																							
Z	2012	Malibu (Eighth Gen)	Body	Steering Column Lock Control Module																																																												
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Engine Control Module																																																												
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Transmission Control Module																																																												
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Engine Control Module																																																												
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 1																																																												
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 2																																																												
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module																																																												
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 6 Speed (MNM)																																																												
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 8 Speed (MRC)																																																												
Z	2016	Malibu	Chassis	Electronic Brake Control Module																																																												
Z	2016	Malibu	Chassis	Brake Booster Control Module																																																												
Z	2016	Malibu	Chassis	Power Steering Control Module																																																												
Z	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
Z	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
Z	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
Z	2016	Malibu	Body	Passenger Presence Module																																																												
Z	2016	Malibu	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
Z	2016	Malibu	Body	Instrument Cluster Enhanced Monochrome Driver Info Center (UDC)																																																												
Z	2016	Malibu	Body	Radio Controls																																																												
Z	2016	Malibu	Body	HVAC Controls																																																												
Z	2016	Malibu	Body	Active Safety Control Module																																																												
Z	2016	Malibu	Body	Headlamp Control Module																																																												
Z	2016	Malibu	Body	Radio Base																																																												
Z	2016	Malibu	Body	Radio (IOA)																																																												
Z	2016	Malibu	Body	Radio Uplevel (IO4 IO5 IO6)																																																												
Z	2016	Malibu	Body	Amplifier																																																												
Z	2016	Malibu	Body	Human Machine Interface Control Module																																																												
Z	2016	Malibu	Body	Navigation Control Module																																																												
Z	2016	Malibu	Body	Mobile Telephone Control Module																																																												
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																												
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																												
Z	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																											V																																	
Z	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																											V																																	
Z	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																											V																																	
Z	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																											V																																	

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
Z	2016	Malibu	Body	Electric A/C Compressor Control Module																																																										
Z	2016	Malibu	Body	Seat Memory Control Module - Driver																																																										
Z	2016	Malibu	Body	Keyless Entry Control Module																																																										
Z	2016	Malibu	Body	Right Side Object Detection Control Module																																																										
Z	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
Z	2016	Malibu	Body	Parking Assist Control Module																																																										
Z	2016	Malibu	Body	Frontview Camera Module																																																										
Z	2016	Malibu	Body	Frontview Camera Module																																																										
Z	2016	Malibu	Body	Steering Column Lock Control Module																																																										
Z	2016	Malibu	Body	Long Range Radar Sensor Module																																																										
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Fuel Pump Control Module																										V																																
1	2013	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Fuel Pump Control Module																										V																																
1	2013	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
1	2013	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2013	Malibu	Chassis	Parking Brake Control Module																																																										
1	2013	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2013	Malibu	Chassis	Power Steering Control Module																																																										
1	2013	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2013	Malibu	Chassis	Suspension Control Module																																																										
1	2013	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2013	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																											
1	2013	Malibu	Body	Passenger Presence Module																																																												
1	2013	Malibu	Body	Instrument Cluster																																																												
1	2013	Malibu	Body	Headlamp Control Module																																																												
1	2013	Malibu	Body	Radio																																																												
1	2013	Malibu	Body	Digital Radio Receiver Control Module																																																												
1	2013	Malibu	Body	Multimedia Player Interface Module																																																												
1	2013	Malibu	Body	Mobile Telephone Control Module																																																												
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2013	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																											V																																	
1	2013	Malibu	Body	HVAC Control Module Auto Single (C68)																											V																																	
1	2013	Malibu	Body	HVAC Control Module Manual Single (C67)																											V																																	
1	2013	Malibu	Body	Rear Seat Heating Control Module																																																												
1	2013	Malibu	Body	Keyless Entry Control Module																																																												
1	2013	Malibu	Body	Parking Assist Control Module																																																												
1	2013	Malibu	Body	Vehicle Direction Camera Control Module																					V																																							
1	2013	Malibu	Body	Steering Column Lock Control Module																																																												
1	2013	Malibu	Body	Battery Energy Control Module																																																												
1	2014	Impala	Powertrain	(R) 2.4L LUK Engine Control Module																																																												
1	2014	Impala	Powertrain	(R) 2.4L LUK Transmission Control Module																																																												
1	2014	Impala	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																												
1	2014	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																												
1	2014	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																												
1	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
1	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																												
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																												
1	2014	Impala	Chassis	Electronic Brake Control Module																																																												
1	2014	Impala	Chassis	Distance Sensing Cruise Control Module																																																												
1	2014	Impala	Chassis	Parking Brake Control Module																																																												
1	2014	Impala	Chassis	Power Steering Control Module																																																												
1	2014	Impala	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2014	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
1	2014	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
1	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	Impala	Body	Passenger Presence Module																																																												
1	2014	Impala	Body	Instrument Cluster																																																												
1	2014	Impala	Body	Radio Control																																																												
1	2014	Impala	Body	HVAC Control																																																												
1	2014	Impala	Body	Radio																																																												
1	2014	Impala	Body	Amplifier																																																												
1	2014	Impala	Body	Human Machine Interface Control Module																																																												
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Impala	Body	HVAC Control Module																																																												
1	2014	Impala	Body	Keyless Entry Control Module																																																												
1	2014	Impala	Body	Right Side Object Detection Control Module																																																												
1	2014	Impala	Body	Left Side Object Detection Control Module																																																												
1	2014	Impala	Body	Parking Assist Control Module																																																												
1	2014	Impala	Body	Frontview Camera Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2014	Impala	Body	Steering Column Lock Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
1	2014	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																												
1	2014	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																												
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																												
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																												
1	2014	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																												
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																												
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																												
1	2014	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																												
1	2014	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																												
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																												
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																												
1	2014	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																										V																																			
1	2014	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
1	2014	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																												
1	2014	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																												
1	2014	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																												
1	2014	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																												
1	2014	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																												
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																												
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																												
1	2014	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																										V																																			
1	2014	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																												
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
1	2014	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
1	2014	Malibu	Chassis	Electronic Brake Control Module																																																												
1	2014	Malibu	Chassis	Parking Brake Control Module																																																												
1	2014	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2014	Malibu	Chassis	Power Steering Control Module																																																												
1	2014	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2014	Malibu	Chassis	Suspension Control Module																																																												
1	2014	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
1	2014	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																												
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																												
1	2014	Malibu	Body	Passenger Presence Module																																																												
1	2014	Malibu	Body	Instrument Cluster																																																												
1	2014	Malibu	Body	Headlamp Control Module																																																												
1	2014	Malibu	Body	Radio																																																											
1	2014	Malibu	Body	Digital Radio Receiver Control Module																																																												
1	2014	Malibu	Body	Multimedia Player Interface Module																																																												
1	2014	Malibu	Body	Mobile Telephone Control Module																																																												
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																											V																																	
1	2014	Malibu	Body	HVAC Control Module Auto Single (C68)																											V																																	

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2014	Malibu	Body	HVAC Control Module Manual Single (C67)																											V																																
1	2014	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																											V																																
1	2014	Malibu	Body	Rear Seat Heating Control Module																																																											
1	2014	Malibu	Body	Keyless Entry Control Module																																																											
1	2014	Malibu	Body	Left Side Object Detection Control Module																																																											
1	2014	Malibu	Body	Parking Assist Control Module																																																											
1	2014	Malibu	Body	Frontview Camera Module																					V																																							
1	2014	Malibu	Body	Steering Column Lock Control Module																																																											
1	2015	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																											
1	2015	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2015	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																											
1	2015	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																											
1	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																											
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																											
1	2015	Impala	Chassis	Electronic Brake Control Module																																																											
1	2015	Impala	Chassis	Distance Sensing Cruise Control Module																																																											
1	2015	Impala	Chassis	Parking Brake Control Module																																																											
1	2015	Impala	Chassis	Power Steering Control Module																																																											
1	2015	Impala	Chassis	Power Steering Control Module																																																											
1	2015	Impala	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2015	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2015	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	Impala	Body	Passenger Presence Module																																																											
1	2015	Impala	Body	Instrument Cluster																																																											
1	2015	Impala	Body	Radio Control																																																											
1	2015	Impala	Body	HVAC Control																																																											
1	2015	Impala	Body	Radio																																																											
1	2015	Impala	Body	Amplifier																																																											
1	2015	Impala	Body	Human Machine Interface Control Module																																																											
1	2015	Impala	Body	Telematics Communication Interface Control Module																																																											
1	2015	Impala	Body	HVAC Control Module																																																											
1	2015	Impala	Body	Keyless Entry Control Module																																																											
1	2015	Impala	Body	Right Side Object Detection Control Module																																																											
1	2015	Impala	Body	Left Side Object Detection Control Module																																																											
1	2015	Impala	Body	Parking Assist Control Module																																																											
1	2015	Impala	Body	Frontview Camera Module																																																											
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
1	2015	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
1	2015	Malibu	Powertrain	2.0L LBN Chassis Control Module																										V																																	
1	2015	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																											
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																											
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																											
1	2015	Malibu	Powertrain	2.0L LBS Chassis Control Module																										V																																	
1	2015	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																											
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																											
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																											
1	2015	Malibu	Powertrain	2.0L LTD Chassis Control Module																										V																																	

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2015	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																										
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																										V																																
1	2015	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.4L LE9 Chassis Control Module																										V																																
1	2015	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2015	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																										
1	2015	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																										V																																
1	2015	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																										
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																										V																																
1	2015	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																										
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	3.0L LFW Chassis Control Module																										V																																
1	2015	Malibu	Powertrain	3.0L LFW Transmission Control Module																																																										
1	2015	Malibu	Powertrain	Rear Differential Clutch Control Module																																																										
1	2015	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2015	Malibu	Chassis	Parking Brake Control Module																																																										
1	2015	Malibu	Chassis	Power Steering Control Module																																																										
1	2015	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2015	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2015	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Malibu	Body	Passenger Presence Module																																																										
1	2015	Malibu	Body	Instrument Cluster																																																										
1	2015	Malibu	Body	Headlamp Control Module																																																										
1	2015	Malibu	Body	Radio																																																										
1	2015	Malibu	Body	Digital Radio Receiver Control Module																																																										
1	2015	Malibu	Body	Multimedia Player Interface Module																																																										
1	2015	Malibu	Body	Mobile Telephone Control Module																																																										
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																												V																														
1	2015	Malibu	Body	HVAC Control Module Auto Single (C68)																												V																														
1	2015	Malibu	Body	HVAC Control Module Manual Single (C67)																												V																														
1	2015	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																												V																														
1	2015	Malibu	Body	Front Seat Heating Control Module																																																										
1	2015	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2015	Malibu	Body	Keyless Entry Control Module																																																										
1	2015	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2015	Malibu	Body	Parking Assist Control Module																					V																																					
1	2015	Malibu	Body	Frontview Camera Module																						V																																				
1	2015	Malibu	Body	Steering Column Lock Control Module																																																										
1	2015	Malibu (LSG)	Powertrain	1.6L LLU Engine Control Module																																																										
1	2015	Malibu (LSG)	Powertrain	Transmission Control Module																																																										
1	2015	Malibu (LSG)	Powertrain	Rear Differential Clutch Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2015	Malibu (LSG)	Chassis	Electronic Brake Control Module																																																										
1	2015	Malibu (LSG)	Chassis	Parking Brake Control Module																																																										
1	2015	Malibu (LSG)	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Malibu (LSG)	Chassis	Suspension Control Module																																																										
1	2015	Malibu (LSG)	Body	Body Control Module																																																										
1	2015	Malibu (LSG)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Malibu (LSG)	Body	Instrument Cluster																																																										
1	2015	Malibu (LSG)	Body	Headlamp Control Module																																																										
1	2015	Malibu (LSG)	Body	Radio																																																										
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Malibu (LSG)	Body	HVAC Control Module																											V																															
1	2015	Malibu (LSG)	Body	Front Seat Heating Control Module																																																										
1	2015	Malibu (LSG)	Body	Keyless Entry Control Module																																																										
1	2015	Malibu (LSG)	Body	Left Side Object Detection Control Module																																																										
1	2015	Malibu (LSG)	Body	Parking Assist Control Module																																																										
1	2015	Malibu (LSG)	Body	Frontview Camera Module																																																										
1	2015	Malibu (LSG)	Body	Steering Column Lock Control Module																																																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2016	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																										
1	2016	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																										
1	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2016	Impala	Powertrain	Chassis Control Module																																																										
1	2016	Impala	Chassis	Electronic Brake Control Module																																																										
1	2016	Impala	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Impala	Chassis	Parking Brake Control Module																																																										
1	2016	Impala	Chassis	Power Steering Control Module																																																										
1	2016	Impala	Chassis	Power Steering Control Module																																																										
1	2016	Impala	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2016	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Impala	Body	Passenger Presence Module																																																										
1	2016	Impala	Body	Instrument Cluster																																																										
1	2016	Impala	Body	Radio Control																																																										
1	2016	Impala	Body	HVAC Control																																																										
1	2016	Impala	Body	Radio																																																										
1	2016	Impala	Body	Amplifier																																																										
1	2016	Impala	Body	Human Machine Interface Control Module																																																										
1	2016	Impala	Body	Navigation Control Module																																																										
1	2016	Impala	Body	Telematics Communication Interface Control Module																																																										
1	2016	Impala	Body	HVAC Control Module																																																										
1	2016	Impala	Body	Seat Memory Control Module - Driver																																																										
1	2016	Impala	Body	Keyless Entry Control Module																																																										
1	2016	Impala	Body	Right Side Object Detection Control Module																																																										
1	2016	Impala	Body	Left Side Object Detection Control Module																																																										
1	2016	Impala	Body	Parking Assist Control Module																																																										
1	2016	Impala	Body	Frontview Camera Module																																																										
1	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2016	Malibu	Powertrain	Fuel Injector Control Module																																																										
1	2016	Malibu	Powertrain	Chassis Control Module																										V																																
1	2016	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2016	Malibu	Chassis	Parking Brake Control Module																																																										
1	2016	Malibu	Chassis	Power Steering Control Module																																																										
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Malibu	Body	Passenger Presence Module																																																										
1	2016	Malibu	Body	Instrument Cluster																																																										
1	2016	Malibu	Body	Headlamp Control Module																																																										
1	2016	Malibu	Body	Radio																																																										
1	2016	Malibu	Body	Digital Radio Receiver Control Module																																																										
1	2016	Malibu	Body	Multimedia Player Interface Module																																																										
1	2016	Malibu	Body	Mobile Telephone Control Module																																																										
1	2016	Malibu	Body	Telematics Communication Interface Control Module																																																										
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																												V																														
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																												V																														
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																												V																														
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																												V																														
1	2016	Malibu	Body	Seat Memory Control Module																																																										
1	2016	Malibu	Body	Front Seat Heating Control Module																																																										
1	2016	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2016	Malibu	Body	Keyless Entry Control Module																																																										
1	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2016	Malibu	Body	Parking Assist Control Module																																																										
1	2016	Malibu	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2005	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																									
A	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
A	2005	ALL	Powertrain	Transmission Control Module																																																									
A	2005	ALL	Chassis	Power Steering Control Module																																																									
A	2005	ALL	Chassis	Anti-lock Brake System																																																									
A	2005	ALL	Body	Body Control Module																																																									
A	2005	ALL	Body	Digital Radio Receiver																																																									
A	2005	ALL	Body	Instrument Panel																																																									
A	2005	ALL	Body	Radio																																																									
A	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2006	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																									
A	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
A	2006	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																									
A	2006	ALL	Powertrain	Transmission Control Module																																																									
A	2006	ALL	Chassis	Power Steering Control Module																																																									
A	2006	ALL	Chassis	Anti-lock Brake System																																																									
A	2006	ALL	Body	Body Control Module																																																									
A	2006	ALL	Body	Digital Radio Receiver																																																									
A	2006	ALL	Body	Instrument Panel																																																									
A	2006	ALL	Body	Radio																																																									
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2006	ALL	Body	Theft Deterrent Module																																																									
A	2007	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																									
A	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
A	2007	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																									
A	2007	ALL	Powertrain	Transmission Control Module																																																									
A	2007	ALL	Chassis	Power Steering Control Module																																																									
A	2007	ALL	Chassis	Electronic Brake Control Module																																																									
A	2007	ALL	Body	Body Control Module																																																									
A	2007	ALL	Body	Digital Radio Receiver																																																									
A	2007	ALL	Body	Instrument Panel Cluster																																																									
A	2007	ALL	Body	Passenger Presence System																																																									
A	2007	ALL	Body	Personal Audio Link Module																																																									
A	2007	ALL	Body	Radio																																																									
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2007	ALL	Body	Theft Deterrent Module																																																									
A	2008	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																									
A	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
A	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																									
A	2008	ALL	Powertrain	Transmission Control Module																																																									
A	2008	ALL	Chassis	Power Steering Control Module																																																									
A	2008	ALL	Chassis	Electronic Brake Control Module with VSES																																																									
A	2008	ALL	Chassis	Electronic Brake Control Module without VSES																																																									
A	2008	ALL	Body	Body Control Module																																																									
A	2008	ALL	Body	Digital Radio Receiver																																																									
A	2008	ALL	Body	Instrument Panel Cluster																																																									
A	2008	ALL	Body	Passenger Presence System																																																									
A	2008	ALL	Body	Personal Audio Link Module																																																									
A	2008	ALL	Body	Radio																																																									
A	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2008	ALL	Body	Theft Deterrent Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2009	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	ALL	Powertrain	(H)2.2L L4 LAP Engine Control Module																																																										
A	2009	ALL	Powertrain	Transmission Control Module																																																										
A	2009	ALL	Chassis	Power Steering Control Module																																																										
A	2009	ALL	Chassis	Electronic Brake Control Module with VSES																																																										
A	2009	ALL	Chassis	Electronic Brake Control Module without VSES																																																										
A	2009	ALL	Body	Body Control Module																																																										
A	2009	ALL	Body	Digital Radio Receiver																																																										
A	2009	ALL	Body	Instrument Panel Cluster																																																										
A	2009	ALL	Body	Passenger Presence System																																																										
A	2009	ALL	Body	Personal Audio Link Module																																																										
A	2009	ALL	Body	Radio																																																										
A	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2009	ALL	Body	Theft Deterrent Module																																																										
A	2010	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2010	ALL	Powertrain	(5)2.2L L4 LAP Engine Control Module																																																										
A	2010	ALL	Powertrain	Transmission Control Module																																																										
A	2010	ALL	Chassis	Power Steering Control Module																																																										
A	2010	ALL	Chassis	Electronic Brake Control Module with VSES																																																										
A	2010	ALL	Chassis	Electronic Brake Control Module without VSES																																																										
A	2010	ALL	Body	Body Control Module																																																										
A	2010	ALL	Body	Digital Radio Receiver																																																										
A	2010	ALL	Body	Driver Information Center																																																										
A	2010	ALL	Body	Instrument Panel Cluster																																																										
A	2010	ALL	Body	Passenger Presence System																																																										
A	2010	ALL	Body	Personal Audio Link Module																																																										
A	2010	ALL	Body	Radio																																																										
A	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2010	ALL	Body	Theft Deterrent Module																																																										
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																										
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
A	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																										
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2012	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																										
A	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2012	Cobalt	Body	Body Control Module																																																										
A	2012	Cobalt	Body	Passenger Presence Module																																																										
A	2012	Cobalt	Body	Instrument Cluster																																																										
A	2012	Cobalt	Body	Radio																																																										
A	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
A	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																										
A	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2012	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2012	Cobalt	Body	Parking Assist Control Module																																																										
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2013	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	Cobalt	Body	Body Control Module																																																										
A	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	Cobalt	Body	Instrument Cluster																																																										
A	2013	Cobalt	Body	Radio																																																										
A	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																										
A	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
A	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2013	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2013	Cobalt	Body	Parking Assist Control Module																																																										
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2014	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	Cobalt	Body	Body Control Module																																																										
A	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	Cobalt	Body	Instrument Cluster																																																										
A	2014	Cobalt	Body	Radio																																																										
A	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2014	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2014	Cobalt	Body	Parking Assist Control Module																																																										
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2015	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	Cobalt	Body	Body Control Module																																																										
A	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	Cobalt	Body	Instrument Cluster																																																										
A	2015	Cobalt	Body	Radio																																																										
A	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																										
A	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
A	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2015	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2015	Cobalt	Body	Parking Assist Control Module																																																										
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2016	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	Cobalt	Body	Body Control Module																																																										
A	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	Cobalt	Body	Instrument Cluster																																																										
A	2016	Cobalt	Body	Radio Other																																																										
A	2016	Cobalt	Body	Radio (IOB)																																																										
A	2016	Cobalt	Body	Radio (UF7)																																																										
A	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2016	Cobalt	Body	Front Seat Heating Control Module																																																										
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																										
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																										
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2010	Beat	Powertrain	Transmission Control Module																																																										
B	2010	Beat	Chassis	Electronic Brake Control Module																																																										
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2010	Beat	Chassis	Power Steering Control Module																																																										
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2010	Beat	Body	Instrument Cluster																																																										
B	2010	Beat	Body	Keyless Entry Control Module																																																										
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																										
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																										
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2011	Beat	Powertrain	Transmission Control Module																																																										
B	2011	Beat	Chassis	Electronic Brake Control Module																																																										
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2011	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2011	Beat	Body	Instrument Cluster																																																										
B	2011	Beat	Body	Keyless Entry Control Module																																																										
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2012	Beat	Powertrain	Transmission Control Module																																																										
B	2012	Beat	Chassis	Electronic Brake Control Module																																																										
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2012	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2012	Beat	Body	Instrument Cluster																																																										
B	2012	Beat	Body	Keyless Entry Control Module																																																										
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2013	Beat	Powertrain	Transmission Control Module																																																										
B	2013	Beat	Chassis	Electronic Brake Control Module																																																										
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2013	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2013	Beat	Body	Instrument Cluster																																																										
B	2013	Beat	Body	Keyless Entry Control Module																																																										
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2014	Beat	Powertrain	Transmission Control Module																																																										
B	2014	Beat	Powertrain	Fuel Injector Control Module																																																										
B	2014	Beat	Chassis	Electronic Brake Control Module																																																										
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
B	2014	Beat	Chassis	Power Steering Control Module																																																										
B	2014	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2014	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2014	Beat	Body	Instrument Cluster																																																										
B	2014	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2015	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2015	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2015	Beat	Powertrain	Transmission Control Module																																																										
B	2015	Beat	Powertrain	Fuel Injector Control Module																																																										
B	2015	Beat	Chassis	Electronic Brake Control Module																																																										
B	2015	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2015	Beat	Chassis	Power Steering Control Module																																																										
B	2015	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2015	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2015	Beat	Body	Instrument Cluster																																																										
B	2015	Beat	Body	Radio																																																										
B	2015	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2015	Beat	Body	Keyless Entry Control Module																																																										
B	2016	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2016	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2016	Beat	Powertrain	Transmission Control Module																																																										
B	2016	Beat	Chassis	Electronic Brake Control Module																																																										
B	2016	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2016	Beat	Chassis	Power Steering Control Module																																																										
B	2016	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2016	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2016	Beat	Body	Instrument Cluster																																																										
B	2016	Beat	Body	Radio																																																										
B	2016	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2016	Beat	Body	HVAC Control Module																																																										
B	2016	Beat	Body	Keyless Entry Control Module																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																										
B	2016	Cruze	Chassis	Electronic Brake Control Module																																																										
B	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																										
B	2016	Cruze	Chassis	Power Steering Control Module																																																										
B	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2016	Cruze	Body	Body Control Module																																																										
B	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2016	Cruze	Body	Passenger Presence Module																																																										
B	2016	Cruze	Body	Instrument Cluster																																																										
B	2016	Cruze	Body	Radio Controls																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
B	2016	Cruze	Body	HVAC Controls																																																										
B	2016	Cruze	Body	Trailer Interface Control Module																																																											
B	2016	Cruze	Body	Radio Base (IO3 IO7)																																																											
B	2016	Cruze	Body	Radio (IOA)																																																											
B	2016	Cruze	Body	Radio (IOB)																																																											
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																											
B	2016	Cruze	Body	Amplifier																																																											
B	2016	Cruze	Body	Multimedia Player Interface Module																																																											
B	2016	Cruze	Body	Human Machine Interface Control Module																																																											
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																											
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																											
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																											
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																											
B	2016	Cruze	Body	Keyless Entry Control Module																																																											
B	2016	Cruze	Body	Right Side Object Detection Control Module																																																											
B	2016	Cruze	Body	Left Side Object Detection Control Module																																																											
B	2016	Cruze	Body	Parking Assist Control Module																																																											
B	2016	Cruze	Body	Frontview Camera Module																																																											
B	2016	Cruze	Body	Steering Column Lock Control Module																																																											
B	2016	Cruze	Body	Long Range Radar Sensor Module																																																											
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2010	Spark	Powertrain	Transmission Control Module																																																											
C	2010	Spark	Chassis	Electronic Brake Control Module																																																											
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2010	Spark	Chassis	Electric Power Steering Control Module																																																											
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2010	Spark	Body	Passenger Presence Module																																																											
C	2010	Spark	Body	Instrument Cluster																																																											
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																											
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																											
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																											
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																											
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																											
C	2011	Spark	Powertrain	Transmission Control Module																																																											
C	2011	Spark	Chassis	Electronic Brake Control Module																																																											
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2011	Spark	Chassis	Electric Power Steering Control Module																																																											
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2011	Spark	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2011	Spark	Body	Instrument Cluster																																																										
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
C	2012	Spark	Powertrain	Transmission Control Module																																																										
C	2012	Spark	Chassis	Electronic Brake Control Module																																																										
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2012	Spark	Chassis	Electric Power Steering Control Module																																																										
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2012	Spark	Body	Passenger Presence Module																																																										
C	2012	Spark	Body	Instrument Cluster																																																										
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																										
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																										
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2013	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2013	Spark	Chassis	Electronic Brake Control Module																																																										
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2013	Spark	Chassis	Power Steering Control Module																																																										
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2013	Spark	Body	Body Control Module																																																										
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2013	Spark	Body	Passenger Presence Module																																																										
C	2013	Spark	Body	Instrument Cluster																																																										
C	2013	Spark	Body	Radio																																																										
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																										
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
C	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
C	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
C	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2014	Spark	Chassis	Electronic Brake Control Module																																																										
C	2014	Spark	Chassis	Electronic Brake Control Module																																																										
C	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2014	Spark	Chassis	Power Steering Control Module																																																										
C	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Spark	Body	Body Control Module																																																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark	Body	Passenger Presence Module																																																										
C	2014	Spark	Body	Instrument Cluster																																																										
C	2014	Spark	Body	Radio																																																										
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Spark	Body	Keyless Entry Control Module																																																										
C	2014	Spark EV	Powertrain	Engine Control Module																																																										
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
C	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
C	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
C	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
C	2014	Spark EV	Chassis	Power Steering Control Module																																																										
C	2014	Spark EV	Body	Body Control Module																																																										
C	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Spark EV	Body	Passenger Presence Module																																																										
C	2014	Spark EV	Body	Instrument Cluster																																																										
C	2014	Spark EV	Body	Radio																																																										
C	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Spark EV	Body	HVAC Control Module																																																										
C	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2014	Spark EV	Body	Coolant Heater Control Module																																																										
C	2014	Spark EV	Body	Keyless Entry Control Module																																																										
C	2014	Spark EV	Body	Battery Charger Control Module																																																										
C	2014	Spark EV	Body	DC Charging Control Module																																																										
C	2014	Spark EV	Body	Battery Energy Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
C	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
C	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
C	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																											
C	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																											
C	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
C	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
C	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
C	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2015	Spark	Powertrain	Fuel Injector Control Module																																																											
C	2015	Spark	Chassis	Electronic Brake Control Module																																																											
C	2015	Spark	Chassis	Electronic Brake Control Module																																																											
C	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2015	Spark	Chassis	Power Steering Control Module																																																											
C	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Spark	Body	Body Control Module																																																											
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Spark	Body	Passenger Presence Module																																																											
C	2015	Spark	Body	Instrument Cluster																																																											
C	2015	Spark	Body	Instrument Cluster																																																											
C	2015	Spark	Body	Tire Pressure Indicator Module																																																											
C	2015	Spark	Body	Radio																																																											
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2015	Spark	Body	Keyless Entry Control Module																																																											
C	2015	Spark EV	Powertrain	Engine Control Module																																																											
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
C	2015	Spark EV	Powertrain	Drive Motor Control Module																																																											
C	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
C	2015	Spark EV	Chassis	Electronic Brake Control Module																																																											
C	2015	Spark EV	Chassis	Parking Brake Control Module																																																											
C	2015	Spark EV	Chassis	Power Steering Control Module																																																											
C	2015	Spark EV	Body	Body Control Module																																																											
C	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
C	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Spark EV	Body	Passenger Presence Module																																																											
C	2015	Spark EV	Body	Instrument Cluster																																																											
C	2015	Spark EV	Body	Radio																																																										
C	2015	Spark EV	Body	HVAC Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2015	Spark EV	Body	Coolant Heater Control Module																																																											
C	2015	Spark EV	Body	Keyless Entry Control Module																																																											
C	2015	Spark EV	Body	Battery Charger Control Module																																																											
C	2015	Spark EV	Body	DC Charging Control Module																																																											
C	2015	Spark EV	Body	Battery Energy Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	Fuel Injector Control Module																																																											
C	2016	Spark	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2016	Spark	Chassis	Power Steering Control Module																																																											
C	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Spark	Body	Body Control Module																																																											
C	2016	Spark	Body	Body Control Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Instrument Cluster																																																											
C	2016	Spark	Body	Instrument Cluster																																																											
C	2016	Spark	Body	Radio																																																											
C	2016	Spark	Body	Telematics Communication Interface Control Module																																																											
C	2016	Spark	Body	Keyless Entry Control Module																																																											
C	2016	Spark EV	Powertrain	Engine Control Module																																																											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
C	2016	Spark EV	Powertrain	Drive Motor Control Module																																																											
C	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
C	2016	Spark EV	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark EV	Chassis	Parking Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2016	Spark EV	Chassis	Power Steering Control Module																																																										
C	2016	Spark EV	Body	Body Control Module																																																										
C	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Spark EV	Body	Passenger Presence Module																																																										
C	2016	Spark EV	Body	Instrument Cluster																																																										
C	2016	Spark EV	Body	Radio																																																										
C	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
C	2016	Spark EV	Body	HVAC Control Module																																																										
C	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2016	Spark EV	Body	Coolant Heater Control Module																																																										
C	2016	Spark EV	Body	Keyless Entry Control Module																																																										
C	2016	Spark EV	Body	Frontview Camera Module																																																										
C	2016	Spark EV	Body	Battery Charger Control Module																																																										
C	2016	Spark EV	Body	DC Charging Control Module																																																										
C	2016	Spark EV	Body	Battery Energy Control Module																																																										
D	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2010	Spark	Powertrain	Transmission Control Module																																																										
D	2010	Spark	Chassis	Electronic Brake Control Module																																																										
D	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2010	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2010	Spark	Body	Passenger Presence Module																																																										
D	2010	Spark	Body	Instrument Cluster																																																										
D	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										
D	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
D	2011	Spark	Powertrain	Transmission Control Module																																																										
D	2011	Spark	Chassis	Electronic Brake Control Module																																																										
D	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2011	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2011	Spark	Body	Passenger Presence Module																																																										
D	2011	Spark	Body	Instrument Cluster																																																										
D	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										
D	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																											
D	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																											
D	2012	Spark	Powertrain	Transmission Control Module																																																											
D	2012	Spark	Chassis	Electronic Brake Control Module																																																											
D	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2012	Spark	Chassis	Electric Power Steering Control Module																																																											
D	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2012	Spark	Body	Passenger Presence Module																																																											
D	2012	Spark	Body	Instrument Cluster																																																											
D	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
D	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
D	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																											
D	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																											
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
D	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
D	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																											
D	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																											
D	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
D	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2013	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2013	Spark	Chassis	Electronic Brake Control Module																																																											
D	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2013	Spark	Chassis	Power Steering Control Module																																																											
D	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2013	Spark	Body	Body Control Module																																																											
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2013	Spark	Body	Passenger Presence Module																																																											
D	2013	Spark	Body	Instrument Cluster																																																											
D	2013	Spark	Body	Radio																																																											
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
D	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
D	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																											
D	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
D	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
D	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2014	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2014	Spark	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2014	Spark	Chassis	Power Steering Control Module																																																											
D	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2014	Spark	Body	Body Control Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark	Body	Passenger Presence Module																																																											
D	2014	Spark	Body	Instrument Cluster																																																											
D	2014	Spark	Body	Radio																																																											
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark	Body	Keyless Entry Control Module																																																											
D	2014	Spark EV	Powertrain	Engine Control Module																																																											
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
D	2014	Spark EV	Powertrain	Drive Motor Control Module																																																											
D	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
D	2014	Spark EV	Chassis	Electronic Brake Control Module																																																											
D	2014	Spark EV	Chassis	Parking Brake Control Module																																																											
D	2014	Spark EV	Chassis	Power Steering Control Module																																																											
D	2014	Spark EV	Body	Body Control Module																																																											
D	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
D	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2014	Spark EV	Body	Passenger Presence Module																																																											
D	2014	Spark EV	Body	Instrument Cluster																																																											
D	2014	Spark EV	Body	Radio																																																											
D	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark EV	Body	HVAC Control Module																																																											
D	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																											
D	2014	Spark EV	Body	Coolant Heater Control Module																																																											
D	2014	Spark EV	Body	Keyless Entry Control Module																																																											
D	2014	Spark EV	Body	Battery Charger Control Module																																																											
D	2014	Spark EV	Body	DC Charging Control Module																																																											
D	2014	Spark EV	Body	Battery Energy Control Module																																																											
D	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
D	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
D	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																									
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2015	Spark	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2015	Spark	Chassis	Power Steering Control Module																																																										
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2015	Spark	Body	Body Control Module																																																										
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark	Body	Passenger Presence Module																																																										
D	2015	Spark	Body	Instrument Cluster																																																										
D	2015	Spark	Body	Instrument Cluster																																																										
D	2015	Spark	Body	Tire Pressure Indicator Module																																																										
D	2015	Spark	Body	Radio																																																										
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2015	Spark	Body	Keyless Entry Control Module																																																										
D	2015	Spark EV	Powertrain	Engine Control Module																																																										
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
D	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
D	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
D	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
D	2015	Spark EV	Chassis	Power Steering Control Module																																																										
D	2015	Spark EV	Body	Body Control Module																																																										
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2015	Spark EV	Body	Passenger Presence Module																																																										
D	2015	Spark EV	Body	Instrument Cluster																																																										
D	2015	Spark EV	Body	Radio																																																										
D	2015	Spark EV	Body	HVAC Control Module																																																										
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
D	2015	Spark EV	Body	Coolant Heater Control Module																																																										
D	2015	Spark EV	Body	Keyless Entry Control Module																																																										
D	2015	Spark EV	Body	Battery Charger Control Module																																																										
D	2015	Spark EV	Body	DC Charging Control Module																																																										
D	2015	Spark EV	Body	Battery Energy Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
D	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
D	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																										
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
D	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2016	Spark	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2016	Spark	Chassis	Power Steering Control Module																																																										
D	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2016	Spark	Body	Body Control Module																																																									
D	2016	Spark	Body	Body Control Module																																																									
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark	Body	Instrument Cluster																																																									
D	2016	Spark	Body	Instrument Cluster																																																									
D	2016	Spark	Body	Radio																																																									
D	2016	Spark	Body	Telematics Communication Interface Control Module																																																										
D	2016	Spark	Body	Keyless Entry Control Module																																																										
D	2016	Spark EV	Powertrain	Engine Control Module																																																										
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
D	2016	Spark EV	Powertrain	Drive Motor Control Module																																																										
D	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
D	2016	Spark EV	Chassis	Electronic Brake Control Module																																																										
D	2016	Spark EV	Chassis	Parking Brake Control Module																																																										
D	2016	Spark EV	Chassis	Power Steering Control Module																																																										
D	2016	Spark EV	Body	Body Control Module																																																										
D	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
D	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2016	Spark EV	Body	Passenger Presence Module																																																										
D	2016	Spark EV	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2016	Spark EV	Body	Radio																																																										
D	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
D	2016	Spark EV	Body	HVAC Control Module																																																										
D	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
D	2016	Spark EV	Body	Coolant Heater Control Module																																																										
D	2016	Spark EV	Body	Keyless Entry Control Module																																																										
D	2016	Spark EV	Body	Frontview Camera Module																																																										
D	2016	Spark EV	Body	Battery Charger Control Module																																																										
D	2016	Spark EV	Body	DC Charging Control Module																																																										
D	2016	Spark EV	Body	Battery Energy Control Module																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Automatic Transmission																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Manual Transmission																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																										
F	2010	Camaro	Powertrain	(V) 3.6L LLT Transmission Control Module																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																										
F	2010	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																										
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2010	Camaro	Chassis	Electronic Brake Control Module																																																										
F	2010	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																										
F	2010	Camaro	Chassis	Power Steering Control Module																																																										
F	2010	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2010	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
F	2010	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
F	2010	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2010	Camaro	Body	Passenger Presence Module																																																										
F	2010	Camaro	Body	Instrument Cluster																																																										
F	2010	Camaro	Body	Auxiliary Gage Module																																																										
F	2010	Camaro	Body	Radio																																																										
F	2010	Camaro	Body	Multimedia Player Interface Module																																																										
F	2010	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																										
F	2010	Camaro	Body	Mobile Telephone Control Module																																																										
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																										
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2010	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																										
F	2010	Camaro	Body	Front Seat Heating Control Module																																																										
F	2010	Camaro	Body	Folding Top Control Module																																																										
F	2010	Camaro	Body	Parking Assist Control Module																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Automatic Transmission																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Manual Transmission																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																										
F	2011	Camaro	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																										
F	2011	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																										
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																											
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2011	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2011	Camaro	Chassis	Power Steering Control Module																																																											
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2011	Camaro	Body	Passenger Presence Module																																																											
F	2011	Camaro	Body	Instrument Cluster																																																											
F	2011	Camaro	Body	Head-Up Display Module																																																											
F	2011	Camaro	Body	Auxiliary Gage Module																																																											
F	2011	Camaro	Body	Headlamp Control Module																																																											
F	2011	Camaro	Body	Radio																																																											
F	2011	Camaro	Body	Multimedia Player Interface Module																																																											
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																											
F	2011	Camaro	Body	Mobile Telephone Control Module																																																											
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																											
F	2011	Camaro	Body	Front Seat Heating Control Module																																																											
F	2011	Camaro	Body	Folding Top Control Module																																																											
F	2011	Camaro	Body	Parking Assist Control Module																																																											
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																											
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																											
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																											
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																											
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module																																																											
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																											
F	2012	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2012	Camaro	Chassis	Power Steering Control Module																																																											
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2012	Camaro	Chassis	Suspension Control Module																																																											
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2012	Camaro	Body	Passenger Presence Module																																																											
F	2012	Camaro	Body	Instrument Cluster																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
F	2012	Camaro	Body	Head-Up Display Module																																																												
F	2012	Camaro	Body	Auxiliary Gage Module																																																												
F	2012	Camaro	Body	Headlamp Control Module																																																												
F	2012	Camaro	Body	Radio																																																												
F	2012	Camaro	Body	Multimedia Player Interface Module																																																												
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																												
F	2012	Camaro	Body	Mobile Telephone Control Module																																																												
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																												
F	2012	Camaro	Body	Front Seat Heating Control Module																																																												
F	2012	Camaro	Body	Folding Top Control Module																																																												
F	2012	Camaro	Body	Parking Assist Control Module																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																												
F	2013	Camaro	Chassis	Electronic Brake Control Module																																																													
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2013	Camaro	Chassis	Power Steering Control Module																																																												
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2013	Camaro	Chassis	Suspension Control Module																																																												
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2013	Camaro	Body	Passenger Presence Module																																																												
F	2013	Camaro	Body	Instrument Cluster																																																												
F	2013	Camaro	Body	Head-Up Display Module																																																												
F	2013	Camaro	Body	Auxiliary Gage Module																																																												
F	2013	Camaro	Body	Headlamp Control Module																																																												
F	2013	Camaro	Body	Radio																																																											
F	2013	Camaro	Body	Multimedia Player Interface Module																																																											
F	2013	Camaro	Body	Mobile Telephone Control Module																																																											
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
F	2013	Camaro	Body	HVAC Control Module																																																										
F	2013	Camaro	Body	Front Seat Heating Control Module																																																											
F	2013	Camaro	Body	Folding Top Control Module																																																											
F	2013	Camaro	Body	Parking Assist Control Module																																																											
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																											
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																											
F	2014	Camaro	Powertrain	Transmission Control Module																																																											
F	2014	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2014	Camaro	Chassis	Parking Brake Control Module																																																											
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2014	Camaro	Chassis	Power Steering Control Module																																																											
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2014	Camaro	Chassis	Suspension Control Module																																																											
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2014	Camaro	Body	Passenger Presence Module																																																											
F	2014	Camaro	Body	Instrument Cluster																																																											
F	2014	Camaro	Body	Head-Up Display Module																																																											
F	2014	Camaro	Body	Auxiliary Gage Module																																																											
F	2014	Camaro	Body	Headlamp Control Module																																																											
F	2014	Camaro	Body	Radio																																																											
F	2014	Camaro	Body	Mobile Telephone Control Module																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2014	Camaro	Body	HVAC Control Module																																																											
F	2014	Camaro	Body	Front Seat Heating Control Module																																																											
F	2014	Camaro	Body	Folding Top Control Module																																																											
F	2014	Camaro	Body	Parking Assist Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2014	SS	Powertrain	Chassis Control Module																																																											
F	2014	SS	Chassis	Electronic Brake Control Module																																																											
F	2014	SS	Chassis	Parking Brake Control Module																																																											
F	2014	SS	Chassis	Power Steering Control Module																																																											
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2014	SS	Body	Body Control Module																																																											
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2014	SS	Body	Passenger Presence Module																																																											
F	2014	SS	Body	Instrument Cluster																																																											
F	2014	SS	Body	Head-Up Display Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
F	2014	SS	Body	Radio Control																																																									
F	2014	SS	Body	HVAC Control																																																									
F	2014	SS	Body	Headlamp Control Module																																																									
F	2014	SS	Body	Trailer Interface Control Module																																																									
F	2014	SS	Body	Radio																																																									
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9																																																									
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10																																																									
F	2014	SS	Body	HVAC Control Module																																																									
F	2014	SS	Body	Seat Memory Control Module - Driver																																																									
F	2014	SS	Body	Keyless Entry Control Module																																																									
F	2014	SS	Body	Right Side Object Detection Control Module																																																									
F	2014	SS	Body	Left Side Object Detection Control Module																																																									
F	2014	SS	Body	Parking Assist Control Module																																																									
F	2014	SS	Body	Frontview Camera Module																																																									
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																									
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																									
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																									
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																									
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																									
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																									
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																									
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																									
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																									
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																									
F	2015	Camaro	Powertrain	Transmission Control Module																																																									
F	2015	Camaro	Chassis	Electronic Brake Control Module																																																									
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																									
F	2015	Camaro	Chassis	Power Steering Control Module																																																									
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																									
F	2015	Camaro	Chassis	Suspension Control Module																																																									
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
F	2015	Camaro	Body	Passenger Presence Module																																																									
F	2015	Camaro	Body	Instrument Cluster																																																									
F	2015	Camaro	Body	Head-Up Display Module																																																									
F	2015	Camaro	Body	Auxiliary Gage Module																																																									
F	2015	Camaro	Body	Headlamp Control Module																																																									
F	2015	Camaro	Body	Radio																																																									
F	2015	Camaro	Body	Mobile Telephone Control Module																																																									
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6																																																									
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																									
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																									
F	2015	Camaro	Body	HVAC Control Module																																																									
F	2015	Camaro	Body	Front Seat Heating Control Module																																																									
F	2015	Camaro	Body	Folding Top Control Module																																																									
F	2015	Camaro	Body	Parking Assist Control Module																																																									
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																									
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2015	SS	Powertrain	Fuel Injector Control Module																																																											
F	2015	SS	Powertrain	Chassis Control Module																																																											
F	2015	SS	Chassis	Electronic Brake Control Module																																																											
F	2015	SS	Chassis	Parking Brake Control Module																																																											
F	2015	SS	Chassis	Power Steering Control Module																																																											
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2015	SS	Chassis	Suspension Control Module																																																											
F	2015	SS	Body	Body Control Module																																																										
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2015	SS	Body	Passenger Presence Module																																																											
F	2015	SS	Body	Instrument Cluster																																																										
F	2015	SS	Body	Head-Up Display Module																																																										
F	2015	SS	Body	Radio Control																																																										
F	2015	SS	Body	HVAC Control																																																										
F	2015	SS	Body	Headlamp Control Module																																																										
F	2015	SS	Body	Trailer Interface Control Module																																																										
F	2015	SS	Body	Radio																																																										
F	2015	SS	Body	Telematics Communication Interface Control Module																																																											
F	2015	SS	Body	HVAC Control Module																																																										
F	2015	SS	Body	Seat Memory Control Module - Driver																																																											
F	2015	SS	Body	Keyless Entry Control Module																																																											
F	2015	SS	Body	Right Side Object Detection Control Module																																																											
F	2015	SS	Body	Left Side Object Detection Control Module																																																											
F	2015	SS	Body	Parking Assist Control Module																																																											
F	2015	SS	Body	Frontview Camera Module																																																											
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																											
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																											
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																											
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																											
F	2016	Camaro	Powertrain	Transmission Control Module																																																											
F	2016	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2016	Camaro	Chassis	Parking Brake Control Module																																																											
F	2016	Camaro	Chassis	Power Steering Control Module																																																											
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2016	Camaro	Chassis	Suspension Control Module																																																											
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2016	Camaro	Body	Serial Data Gateway Module																																																											
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2016	Camaro	Body	Passenger Presence Module																																																											
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																											
F	2016	Camaro	Body	Head-Up Display Module																																																											
F	2016	Camaro	Body	Auxiliary Gage Module																																																											
F	2016	Camaro	Body	Radio Controls																																																											
F	2016	Camaro	Body	HVAC Controls																																																											
F	2016	Camaro	Body	Vehicle Performance Data Recorder																																																											
F	2016	Camaro	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
F	2016	Camaro	Body	Amplifier																																																								
F	2016	Camaro	Body	Media Disc Player																																																								
F	2016	Camaro	Body	Human Machine Interface Control Module																																																								
F	2016	Camaro	Body	Navigation Control Module																																																								
F	2016	Camaro	Body	Mobile Telephone Control Module																																																								
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																								
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)																																																								
F	2016	Camaro	Body	Seat Memory Control Module - Driver																																																								
F	2016	Camaro	Body	Folding Top Control Module																																																								
F	2016	Camaro	Body	Keyless Entry Control Module																																																								
F	2016	Camaro	Body	Right Side Object Detection Control Module																																																								
F	2016	Camaro	Body	Left Side Object Detection Control Module																																																								
F	2016	Camaro	Body	Parking Assist Control Module																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2016	SS	Powertrain	Fuel Injector Control Module																																																								
F	2016	SS	Chassis	Electronic Brake Control Module																																																								
F	2016	SS	Chassis	Parking Brake Control Module																																																								
F	2016	SS	Chassis	Power Steering Control Module																																																								
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2016	SS	Chassis	Suspension Control Module																																																								
F	2016	SS	Body	Body Control Module																																																								
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2016	SS	Body	Passenger Presence Module																																																								
F	2016	SS	Body	Instrument Cluster																																																								
F	2016	SS	Body	Head-Up Display Module																																																								
F	2016	SS	Body	Radio Control																																																								
F	2016	SS	Body	HVAC Control																																																								
F	2016	SS	Body	Trailer Interface Control Module																																																								
F	2016	SS	Body	Radio																																																								
F	2016	SS	Body	Telematics Communication Interface Control Module																																																								
F	2016	SS	Body	HVAC Control Module																																																								
F	2016	SS	Body	Seat Memory Control Module - Driver																																																								
F	2016	SS	Body	Keyless Entry Control Module																																																								
F	2016	SS	Body	Right Side Object Detection Control Module																																																								
F	2016	SS	Body	Left Side Object Detection Control Module																																																								
F	2016	SS	Body	Parking Assist Control Module																																																								
F	2016	SS	Body	Frontview Camera Module																																																								
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
G	2016	Malibu	Powertrain	Fuel Injector Control Module																																																								
G	2016	Malibu	Powertrain	Chassis Control Module																																																								
G	2016	Malibu	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2016	Malibu	Chassis	Parking Brake Control Module																																																										
G	2016	Malibu	Chassis	Power Steering Control Module																																																											
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																											
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
G	2016	Malibu	Body	Passenger Presence Module																																																												
G	2016	Malibu	Body	Instrument Cluster																																																												
G	2016	Malibu	Body	Headlamp Control Module																																																												
G	2016	Malibu	Body	Radio																																																											
G	2016	Malibu	Body	Digital Radio Receiver Control Module																																																											
G	2016	Malibu	Body	Multimedia Player Interface Module																																																											
G	2016	Malibu	Body	Mobile Telephone Control Module																																																											
G	2016	Malibu	Body	Telematics Communication Interface Control Module																																																											
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																											
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																											
G	2016	Malibu	Body	Seat Memory Control Module																																																											
G	2016	Malibu	Body	Front Seat Heating Control Module																																																											
G	2016	Malibu	Body	Rear Seat Heating Control Module																																																											
G	2016	Malibu	Body	Keyless Entry Control Module																																																											
G	2016	Malibu	Body	Left Side Object Detection Control Module																																																											
G	2016	Malibu	Body	Parking Assist Control Module																																																											
G	2016	Malibu	Body	Frontview Camera Module																																																											
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																											
H	2010	Sail	Powertrain	Transmission Control Module																																																											
H	2010	Sail	Chassis	Electronic Brake Control Module																																																											
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																											
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																											
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																											
H	2011	Sail	Powertrain	Transmission Control Module																																																											
H	2011	Sail	Chassis	Electronic Brake Control Module																																																											
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																											
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																											
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																											
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																											
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
H	2012	Sail	Powertrain	Transmission Control Module																																																											
H	2012	Sail	Chassis	Electronic Brake Control Module																																																											
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	Transmission Control Module																																																										
H	2013	Sail	Chassis	Electronic Brake Control Module																																																										
H	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	Transmission Control Module																																																										
H	2014	Sail	Chassis	Electronic Brake Control Module																																																										
H	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																										
H	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																										
H	2015	Sail	Chassis	Electronic Brake Control Module																																																										
H	2015	Sail	Chassis	Power Steering Control Module																																																										
H	2015	Sail	Body	Body Control Module																																																									
H	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Sail	Body	Radio/HVAC Control																																																										
H	2015	Sail	Body	HVAC Control Module																																																										
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
H	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																										
H	2016	Sail	Chassis	Electronic Brake Control Module																																																										
H	2016	Sail	Chassis	Power Steering Control Module																																																										
H	2016	Sail	Body	Body Control Module																																																									
H	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Sail	Body	Radio/HVAC Control																																																										
H	2016	Sail	Body	Radio																																																										
H	2016	Sail	Body	HVAC Control Module																																																										
J	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
J	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
J	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
J	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
J	2004	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
J	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
J	2004	Optra	Body	Remote Function Actuation																																																										
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel																																																										
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel Transmission Control Module																																																										
J	2004	Cavalier	Chassis	Anti-lock Brake System																																																										
J	2004	Cavalier	Body	Body Control Module																																																										
J	2004	Cavalier	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2004	Cavalier	Body	Instrument Panel Cluster																																																										
J	2004	Cavalier	Body	Radio																																																										
J	2004	Cavalier	Body	Supplemental Inflatable Restraint																																																										
J	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
J	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
J	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
J	2005	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
J	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
J	2005	Optra	Body	Remote Function Actuation																																																										
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
J	2005	Cavalier	Chassis	Anti-lock Brake System																																																										
J	2005	Cavalier	Body	Body Control Module																																																										
J	2005	Cavalier	Body	Digital Radio Receiver																																																										
J	2005	Cavalier	Body	Instrument Panel Cluster																																																										
J	2005	Cavalier	Body	Radio																																																										
J	2005	Cavalier	Body	Supplemental Inflatable Restraint																																																										
J	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
J	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
J	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
J	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
J	2006	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
J	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
J	2006	ALL	Body	Remote Function Actuation																																																										
J	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
J	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
J	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
J	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
J	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																		
J	2007	ALL	Powertrain	4 Speed Automatic																																																										
J	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																										
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																										
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																										
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																										
J	2007	ALL	Chassis	Tire Pressure Monitor									V	V																																															
J	2007	ALL	Body	Remote Function Actuation																																																										
J	2007	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
J	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
J	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																		
J	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																		
J	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																											
J	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2008	ALL	Chassis	Tire Pressure Monitor									V	V																																																	
J	2008	ALL	Body	Remote Function Actuation																																																											
J	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
J	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
J	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
J	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																		
J	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																											
J	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2009	ALL	Chassis	Tire Pressure Monitor									V	V																																																	
J	2009	ALL	Body	Remote Function Actuation																																																											
J	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																														
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission											V	V																																														
J	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																											
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission													V	V																																											
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission													V	V																																											
J	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																											
J	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission													V	V																																											
J	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission													V	V																																											
J	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission															V	V	V	V	V																																							
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission															V	V	V	V	V																																							
J	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																											
J	2010	Cruze	Chassis	Electronic Brake Control Module																																																											
J	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2010	Cruze	Body	Body Control Module																				V																																							
J	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2010	Cruze	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2010	Cruze	Body	Instrument Cluster																																																											
J	2010	Cruze	Body	Trailer Interface Control Module																																																												
J	2010	Cruze	Body	Radio																																																											
J	2010	Cruze	Body	Multimedia Player Interface Module																																																											
J	2010	Cruze	Body	Mobile Telephone Control Module																																																											
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
J	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
J	2010	Cruze	Body	Keyless Entry Control Module																																																											
J	2010	Cruze	Body	Parking Assist Control Module																																																											
J	2010	Cruze	Body	Steering Column Lock Control Module																																																											
J	2010	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2010	Other	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
J	2010	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2010	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																			
J	2010	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2010	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2010	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2010	Other	Powertrain	Transmission Control Module 5 Speed																																																											
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2010	Other	Chassis	Tire Pressure Monitor									V	V																																																	
J	2010	Other	Body	Remote Function Actuation																																																											
J	2010	Other	Body	Supplemental Inflatable Restraint																					V	V																																					
J	2010	Other	Body	Supplemental Inflatable Restraint																																																											
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																		
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																		
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																											
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																											
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission											V	V																																														
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission											V	V																																														
J	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission													V	V																																											
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission													V	V																																											
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission												V													V	V																																
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission												V													V																																	
J	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																											
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																														
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission											V	V																																														
J	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission													V	V																																											
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission													V	V																																											
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission												V													V	V																																
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission												V													V																																	
J	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission											V													V	V																																	
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission											V														V																																	
J	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
J	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission															V	V	V	V	V																																							

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission															V	V	V	V	V																																					
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																									
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V																			
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V																			
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
J	2011	Cruze	Chassis	Electronic Brake Control Module																																																									
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2011	Cruze	Body	Body Control Module																				V																																						
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2011	Cruze	Body	Passenger Presence Module																																																									
J	2011	Cruze	Body	Instrument Cluster																																																									
J	2011	Cruze	Body	Trailer Interface Control Module																																																									
J	2011	Cruze	Body	Radio																																																									
J	2011	Cruze	Body	Multimedia Player Interface Module																																																									
J	2011	Cruze	Body	Mobile Telephone Control Module																																																									
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
J	2011	Cruze	Body	Keyless Entry Control Module																																																									
J	2011	Cruze	Body	Parking Assist Control Module																																																									
J	2011	Cruze	Body	Steering Column Lock Control Module																																																									
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																									
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																	
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																									
J	2011	Other	Powertrain	Transmission Control Module 5 Speed																																																									
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No																																																									
J	2011	Other	Chassis	Tire Pressure Monitor									V	V																																															
J	2011	Other	Body	Remote Function Actuation																																																									
J	2011	Other	Body	Supplemental Inflatable Restraint																																																									
J	2011	Other	Body	Supplemental Inflatable Restraint																					V	V																																			
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																											
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																											
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2012	Aveo	Powertrain	Fuel Pump Control Module																																																												
J	2012	Aveo	Powertrain	Fuel Injector Control Module																																																												
J	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2012	Aveo	Chassis	Electric Power Steering Control Module																																																											
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2012	Aveo	Body	Body Control Module Hatchback																																																											
J	2012	Aveo	Body	Body Control Module Sedan																																																											
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2012	Aveo	Body	Passenger Presence Module																																																											
J	2012	Aveo	Body	Instrument Cluster																																																											
J	2012	Aveo	Body	Radio																																																											
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																											
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
J	2012	Aveo	Body	Front Seat Heating Control Module																																																											
J	2012	Aveo	Body	Parking Assist Control Module																																																											
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																											
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																											
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2012	Cobalt	Chassis	Electronic Brake Control Module																																																											
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																											
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2012	Cobalt	Body	Body Control Module																																																											
J	2012	Cobalt	Body	Passenger Presence Module																																																											
J	2012	Cobalt	Body	Instrument Cluster																																																											
J	2012	Cobalt	Body	Radio																																																											
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																											
J	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																											
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2012	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2012	Cobalt	Body	Parking Assist Control Module																																																										
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																	
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																	
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																										
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission											V	V																																														
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission											V	V																																														
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission													V	V																																											
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission													V	V																																											
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission												V													V	V																																
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission												V													V																																	
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																										
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																														
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission											V	V																																														
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V			V	V																														
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V			V	V																														
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission													V	V																																											
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission													V	V																																											
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission												V													V	V																																
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission												V													V																																	
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission											V	V							V							V													V	V																	
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission											V	V							V																				V	V																	
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission											V													V	V																																	
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission											V														V																																	
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission															V	V	V	V	V																																						
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission															V	V	V	V	V																																						
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V				V															
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V				V															
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																										
J	2012	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2012	Cruze	Body	Body Control Module Hatchback																				V																																						
J	2012	Cruze	Body	Body Control Module Sedan																				V																																						
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2012	Cruze	Body	Passenger Presence Module																																																										
J	2012	Cruze	Body	Instrument Cluster																																																										
J	2012	Cruze	Body	Trailer Interface Control Module																																																										
J	2012	Cruze	Body	Radio																																																										
J	2012	Cruze	Body	Multimedia Player Interface Module																																																										
J	2012	Cruze	Body	Mobile Telephone Control Module																																																										
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
J	2012	Cruze	Body	Keyless Entry Control Module																																																											
J	2012	Cruze	Body	Parking Assist Control Module																																																											
J	2012	Cruze	Body	Steering Column Lock Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																		
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																											
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor									V	V																																																	
J	2012	Sonic (First Gen)	Body	Remote Function Actuation																																																											
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																											
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																					V	V																																					
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																											
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module Chassis Expansion CAN BUS																																																									
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module High Speed CAN Bus																																																									
J	2012	Sonic (Second Gen)	Body	Body Control Module Hatchback																																										V															
J	2012	Sonic (Second Gen)	Body	Body Control Module Sedan																																										V															
J	2012	Sonic (Second Gen)	Body	Passenger Presence Module																																																									
J	2012	Sonic (Second Gen)	Body	Instrument Cluster																																																									
J	2012	Sonic (Second Gen)	Body	Radio																																																									
J	2012	Sonic (Second Gen)	Body	Telematic Vehicle Localization and Immobilization Control Module																																																									
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																									
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																									
J	2012	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																									
J	2012	Sonic (Second Gen)	Body	Parking Assist Control Module																																																									
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
J	2013	Aveo	Powertrain	Fuel Pump Control Module																																																									
J	2013	Aveo	Powertrain	Fuel Injector Control Module																																																									
J	2013	Aveo	Chassis	Electronic Brake Control Module																																																									
J	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2013	Aveo	Chassis	Electric Power Steering Control Module																																																									
J	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2013	Aveo	Body	Body Control Module Hatchback																																																									
J	2013	Aveo	Body	Body Control Module Sedan																																																									
J	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2013	Aveo	Body	Passenger Presence Module																																																									
J	2013	Aveo	Body	Instrument Cluster																																																									
J	2013	Aveo	Body	Radio																																																									
J	2013	Aveo	Body	Telematics Communication Interface Control Module																																																									
J	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
J	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
J	2013	Aveo	Body	Front Seat Heating Control Module																																																									
J	2013	Aveo	Body	Parking Assist Control Module																																																									
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2013	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Cobalt	Body	Body Control Module																																																										
J	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Cobalt	Body	Instrument Cluster																																																										
J	2013	Cobalt	Body	Radio																																																										
J	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																										
J	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2013	Cobalt	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission												V												V	V																																
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission												V												V																																	
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission											V											V	V	V																																	
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission											V											V	V	V																																	
J	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission											V											V	V	V																																	
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission											V											V	V	V																																	
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission											V	V																																													
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission											V	V																																													
J	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission													V	V																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission													V	V																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission											V	V	V											V	V																																
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission											V	V	V											V																																	
J	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																													
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission											V	V																																													
J	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																							V			V	V																														
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																							V			V	V																														
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																										
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission													V	V																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission											V	V	V												V	V																																
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission											V	V	V												V																																	
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission											V												V	V	V																																	
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission											V												V	V	V																																	
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission											V												V	V	V																																	
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission											V												V	V	V																																	
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V	V			V																	
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V	V			V																	
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2013	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Cruze	Body	Body Control Module Hatchback																				V																								V														
J	2013	Cruze	Body	Body Control Module Sedan																				V																								V														
J	2013	Cruze	Body	Body Control Module Station Wagon																				V																								V														
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Cruze	Body	Passenger Presence Module																																																										
J	2013	Cruze	Body	Instrument Cluster																																																										
J	2013	Cruze	Body	Trailer Interface Control Module																																																										
J	2013	Cruze	Body	Radio																																																										
J	2013	Cruze	Body	Digital Radio Receiver Control Module																																																										
J	2013	Cruze	Body	Multimedia Player Interface Module																																																										
J	2013	Cruze	Body	Mobile Telephone Control Module																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																													V														
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																													V														
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																													V														
J	2013	Cruze	Body	Front Seat Heating Control Module																																																										
J	2013	Cruze	Body	Keyless Entry Control Module																																																										
J	2013	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Body	Steering Column Lock Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																	
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																									
J	2013	Sonic (First Gen)	Chassis	Tire Pressure Monitor									V	V																																															
J	2013	Sonic (First Gen)	Body	Remote Function Actuation																																																										
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																										
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																				V	V																																					
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission											V																																														
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission											V																																														
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Fuel Pump Control Module																																																										
J	2013	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																										
J	2013	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																										
J	2013	Sonic (Second Gen)	Body	Body Control Module Sedan																																																										
J	2013	Sonic (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Sonic (Second Gen)	Body	Passenger Presence Module																																																										
J	2013	Sonic (Second Gen)	Body	Instrument Cluster																																																										
J	2013	Sonic (Second Gen)	Body	Radio																																																										
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																									
J	2013	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																										
J	2013	Sonic (Second Gen)	Body	Parking Assist Control Module																																																										
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2013	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2013	Spin	Chassis	Electronic Brake Control Module																																																										
J	2013	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Spin	Body	Body Control Module																																																										
J	2013	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Spin	Body	Instrument Cluster																																																										
J	2013	Spin	Body	Radio																																																										
J	2013	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Spin	Body	Parking Assist Control Module																																																										
J	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																													V	V											
J	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																													V	V											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																														V	V										
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	Chassis Control Module																																																										
J	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Aveo	Chassis	Power Steering Control Module																																																										
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Aveo	Body	Body Control Module Hatchback																																																										
J	2014	Aveo	Body	Body Control Module Sedan																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Instrument Cluster																																																										
J	2014	Aveo	Body	Radio																																																										
J	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Aveo	Body	Front Seat Heating Control Module																																																										
J	2014	Aveo	Body	Keyless Entry Control Module																																																										
J	2014	Aveo	Body	Parking Assist Control Module																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2014	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Cobalt	Body	Body Control Module																																																										
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Cobalt	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2014	Cobalt	Body	Radio																																																									
J	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									
J	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
J	2014	Cobalt	Body	Front Seat Heating Control Module																																																									
J	2014	Cobalt	Body	Parking Assist Control Module																																																									
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission											V												V	V	V																																
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission											V												V	V	V																																
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																
J	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission											V												V	V	V																																
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission											V												V	V	V																																
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission											V	V																																													
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission											V	V																																													
J	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission													V	V																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission													V	V																																										
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission											V	V	V												V	V																															
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission											V	V	V												V																																
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission											V													V	V																																
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission											V													V	V																																
J	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																												
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission											V	V																																												
J	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																								V		V	V																				V									
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																								V		V	V																				V									
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V		V	V																													
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V		V	V																													
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																									
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission													V	V																																									
J	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission											V	V	V												V	V																														
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission											V	V	V												V																															
J	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission											V												V	V	V																																
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission											V												V	V	V																																
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission											V												V	V	V																																

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission											V												V	V	V																															
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V															
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V															
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																											V							V	V	V	V							V		V	V	V	V	V	V	V	V	V
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																												V																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																								
J	2014	Cruze	Powertrain	Fuel Injector Control Module																																																								
J	2014	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2014	Cruze	Chassis	Power Steering Control Module																																																								
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2014	Cruze	Body	Body Control Module Hatchback																				V																								V												
J	2014	Cruze	Body	Body Control Module Sedan																				V																								V												
J	2014	Cruze	Body	Body Control Module Station Wagon																				V																								V												
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2014	Cruze	Body	Passenger Presence Module																																																								
J	2014	Cruze	Body	Instrument Cluster																																																								
J	2014	Cruze	Body	Trailer Interface Control Module																																																								
J	2014	Cruze	Body	Radio																																																								
J	2014	Cruze	Body	Digital Radio Receiver Control Module																																																								
J	2014	Cruze	Body	Multimedia Player Interface Module																																																								
J	2014	Cruze	Body	Mobile Telephone Control Module																																																								
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																												V												
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																												V												
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																												V												
J	2014	Cruze	Body	Front Seat Heating Control Module																																																								
J	2014	Cruze	Body	Keyless Entry Control Module																																																								
J	2014	Cruze	Body	Right Side Object Detection Control Module																																																								
J	2014	Cruze	Body	Left Side Object Detection Control Module																																																								
J	2014	Cruze	Body	Parking Assist Control Module																																																								
J	2014	Cruze	Body	Steering Column Lock Control Module																																																								
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module																																																								
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2014	Sonic	Powertrain	1.4L LDD Chassis Control Module																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.4L LUJ Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(C) 1.6L LDE Chassis Control Module																																																										
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(H) 1.8L LUW Chassis Control Module																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission											V																																														
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission											V																																														
J	2014	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2014	Sonic	Powertrain	(G) 1.8L LWE Chassis Control Module																																																										
J	2014	Sonic	Powertrain	Fuel Injector Control Module																																																										
J	2014	Sonic	Chassis	Electronic Brake Control Module																																																										
J	2014	Sonic	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Sonic	Chassis	Power Steering Control Module																																																										
J	2014	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Sonic	Body	Body Control Module Hatchback																																																										
J	2014	Sonic	Body	Body Control Module Sedan																																																										
J	2014	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Sonic	Body	Passenger Presence Module																																																										
J	2014	Sonic	Body	Instrument Cluster																																																										
J	2014	Sonic	Body	Radio																																																										
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Sonic	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Sonic	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Sonic	Body	Front Seat Heating Control Module																																																										
J	2014	Sonic	Body	Parking Assist Control Module																																																										
J	2014	Sonic	Body	Frontview Camera Module																																																										
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.5L L2B Transmission Control Module																																																								
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																								
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.8L LMD Transmission Control Module																																																								
J	2014	Spin	Chassis	Electronic Brake Control Module																																																								
J	2014	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2014	Spin	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2014	Spin	Body	Body Control Module																																																								
J	2014	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2014	Spin	Body	Instrument Cluster																																																								
J	2014	Spin	Body	Radio																																																								
J	2014	Spin	Body	HVAC Control Module Heater Only (C41)																																																								
J	2014	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2014	Spin	Body	HVAC Control Module Single Zone (C60)																																																								
J	2014	Spin	Body	Parking Assist Control Module																																																								
J	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																								
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																													V	V										
J	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																													V	V										
J	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																												V	V										
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																								
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
J	2015	Aveo	Powertrain	Chassis Control Module																																																								
J	2015	Aveo	Powertrain	Fuel Injector Control Module																																																								
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																								
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																								
J	2015	Aveo	Chassis	Power Steering Control Module																																																								
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2015	Aveo	Body	Body Control Module Hatchback																																																								
J	2015	Aveo	Body	Body Control Module Sedan																																																								
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Aveo	Body	Instrument Cluster																																																								
J	2015	Aveo	Body	Radio																																																								
J	2015	Aveo	Body	Telematics Communication Interface Control Module																																																								
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								
J	2015	Aveo	Body	Front Seat Heating Control Module																																																								
J	2015	Aveo	Body	Keyless Entry Control Module																																																								
J	2015	Aveo	Body	Parking Assist Control Module																																																								
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																								
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																								
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																								
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																								
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																								
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																								
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																								
J	2015	Cobalt	Chassis	Electronic Brake Control Module																																																								
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2015	Cobalt	Body	Body Control Module																																																								
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Cobalt	Body	Instrument Cluster																																																								
J	2015	Cobalt	Body	Radio																																																								
J	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																								
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
J	2015	Cobalt	Body	Front Seat Heating Control Module																																																											
J	2015	Cobalt	Body	Parking Assist Control Module																																																											
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission											V												V	V	V																																		
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission											V												V	V	V																																		
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																		
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																		
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																											
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission											V												V	V	V																																		
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission											V												V	V	V																																		
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																											
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission											V	V																																															
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission											V	V																																															
J	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission													V	V																																													
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission													V	V																																													
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission											V	V	V												V	V																																		
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission											V	V	V												V																																		
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																											
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission											V													V	V																																		
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission											V													V	V																																		
J	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																											
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																											
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																											
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																															
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission											V	V																																															
J	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																								V		V	V																				V											
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																								V		V	V																				V											
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V		V	V																																
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V		V	V																																
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																												
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission													V	V																																												
J	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission											V	V	V												V	V																																
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission											V	V	V												V																																
J	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																											
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission											V												V	V	V																																	
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission											V												V	V	V																																	
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission											V												V	V	V																															
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission											V												V	V	V																															
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V																	
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V																	
J	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																											V								V	V	V	V								V		V	V	V	V	V	V	V	V	V
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																												V																												
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																								
J	2015	Cruze	Powertrain	Fuel Injector Control Module																																																								
J	2015	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2015	Cruze	Chassis	Power Steering Control Module																																																								
J	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2015	Cruze	Body	Body Control Module Hatchback																				V																							V													
J	2015	Cruze	Body	Body Control Module Sedan																				V																							V													
J	2015	Cruze	Body	Body Control Module Station Wagon																				V																							V													
J	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Cruze	Body	Passenger Presence Module																																																								
J	2015	Cruze	Body	Instrument Cluster																																																								
J	2015	Cruze	Body	Trailer Interface Control Module																																																								
J	2015	Cruze	Body	Radio																																																								
J	2015	Cruze	Body	Digital Radio Receiver Control Module																																																								
J	2015	Cruze	Body	Multimedia Player Interface Module																																																								
J	2015	Cruze	Body	Mobile Telephone Control Module																																																								
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																												V												
J	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																												V												
J	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																												V												
J	2015	Cruze	Body	Front Seat Heating Control Module																																																								
J	2015	Cruze	Body	Keyless Entry Control Module																																																								
J	2015	Cruze	Body	Right Side Object Detection Control Module																																																								
J	2015	Cruze	Body	Left Side Object Detection Control Module																																																								
J	2015	Cruze	Body	Parking Assist Control Module																																																								
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2015	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																										
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	1.6L LED Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2015	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission											V																																															
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission											V																																															
J	2015	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2015	Sonic	Powertrain	Chassis Control Module																																																											
J	2015	Sonic	Powertrain	Fuel Injector Control Module																																																											
J	2015	Sonic	Chassis	Electronic Brake Control Module																																																											
J	2015	Sonic	Chassis	Power Steering Control Module																																																											
J	2015	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2015	Sonic	Body	Body Control Module Hatchback																																																											
J	2015	Sonic	Body	Body Control Module Sedan																																																											
J	2015	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2015	Sonic	Body	Passenger Presence Module																																																											
J	2015	Sonic	Body	Instrument Cluster																																																											
J	2015	Sonic	Body	Radio																																																											
J	2015	Sonic	Body	Telematics Communication Interface Control Module																																																											
J	2015	Sonic	Body	HVAC Control Module Heater Only (C41)																																																											
J	2015	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2015	Sonic	Body	HVAC Control Module Single Zone (C60)																																																											
J	2015	Sonic	Body	Front Seat Heating Control Module																																																											
J	2015	Sonic	Body	Parking Assist Control Module																																																											
J	2015	Sonic	Body	Frontview Camera Module																																																											
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																											
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.5L L2B Transmission Control Module																																																											
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
J	2015	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2015	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2015	Spin	Chassis	Electronic Brake Control Module																																																										
J	2015	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Spin	Body	Body Control Module																																																										
J	2015	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Spin	Body	Instrument Cluster																																																										
J	2015	Spin	Body	Radio																																																										
J	2015	Spin	Body	Telematics Communication Interface Control Module																																																										
J	2015	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Spin	Body	Front Seat Heating Control Module																																																										
J	2015	Spin	Body	Parking Assist Control Module																																																										
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																												V	V													
J	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																												V	V													
J	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
J	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																												V	V													
J	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2016	Aveo	Powertrain	Chassis Control Module																																																										
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
J	2016	Aveo	Chassis	Power Steering Control Module																																																											
J	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Aveo	Body	Body Control Module Hatchback																																																											
J	2016	Aveo	Body	Body Control Module Sedan																																																											
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Aveo	Body	Instrument Cluster																																																											
J	2016	Aveo	Body	Radio																																																											
J	2016	Aveo	Body	Telematics Communication Interface Control Module																																																											
J	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
J	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Aveo	Body	Front Seat Heating Control Module																																																											
J	2016	Aveo	Body	Parking Assist Control Module																																																											
J	2016	Aveo	Body	Keyless Entry Control Module																																																											
J	2016	Aveo	Body	Frontview Camera Module																																																											
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2016	Cobalt	Chassis	Electronic Brake Control Module																																																											
J	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Cobalt	Body	Body Control Module																																																											
J	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Cobalt	Body	Instrument Cluster																																																											
J	2016	Cobalt	Body	Radio Other																																																											
J	2016	Cobalt	Body	Radio (IOB)																																																											
J	2016	Cobalt	Body	Radio (UF7)																																																											
J	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											
J	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Cobalt	Body	Front Seat Heating Control Module																																																											
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																		
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																		
J	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission											V												V	V	V																																		
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission											V												V	V	V																																		
J	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission											V	V																																														
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission											V	V																																														

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission													V	V																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission													V	V																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission											V	V													V	V																																
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission											V	V													V																																
J	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																													
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission											V	V																																													
J	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																											
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission													V	V																																											
J	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission											V	V													V	V																																
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission											V	V													V																																
J	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission											V												V	V	V																																
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission											V												V	V	V																																
J	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission											V												V	V	V																																
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission											V												V	V	V																																
J	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V																	
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V	V			V																	
J	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2016	Cruze	Powertrain	Fuel Injector Control Module																																																										
J	2016	Cruze	Powertrain	Chassis Control Module																																																										
J	2016	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2016	Cruze	Chassis	Power Steering Control Module																																																										
J	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Cruze	Body	Body Control Module Hatchback																																																										
J	2016	Cruze	Body	Body Control Module Sedan																																																										
J	2016	Cruze	Body	Body Control Module Station Wagon																																																										
J	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Cruze	Body	Passenger Presence Module																																																										
J	2016	Cruze	Body	Instrument Cluster																																																										
J	2016	Cruze	Body	Trailer Interface Control Module																																																										
J	2016	Cruze	Body	Radio Other																																																										
J	2016	Cruze	Body	Radio (UF7)																																																										
J	2016	Cruze	Body	Multimedia Player Interface Module																																																										
J	2016	Cruze	Body	Mobile Telephone Control Module																																																										
J	2016	Cruze	Body	Telematics Communication Interface Control Module																																																										
J	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
J	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																										
J	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																										
J	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																										
J	2016	Cruze	Body	Front Seat Heating Control Module																																																										
J	2016	Cruze	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2016	Cruze	Body	Right Side Object Detection Control Module																																																								
J	2016	Cruze	Body	Left Side Object Detection Control Module																																																								
J	2016	Cruze	Body	Parking Assist Control Module																																																								
J	2016	Cruze	Body	Steering Column Lock Control Module																																																								
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																								
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module																																																								
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission										V																																														
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission										V																																														
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2016	Sonic	Powertrain	Chassis Control Module																																																								
J	2016	Sonic	Powertrain	Fuel Injector Control Module																																																								
J	2016	Sonic	Chassis	Electronic Brake Control Module																																																								
J	2016	Sonic	Chassis	Power Steering Control Module																																																								
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2016	Sonic	Body	Body Control Module Hatchback																																																								
J	2016	Sonic	Body	Body Control Module Sedan																																																								
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2016	Sonic	Body	Passenger Presence Module																																																								
J	2016	Sonic	Body	Instrument Cluster																																																								
J	2016	Sonic	Body	Radio Other																																																								
J	2016	Sonic	Body	Radio (UF7)																																																								
J	2016	Sonic	Body	Radio (UH7)																																																								
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7																																																								
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Sonic	Body	Front Seat Heating Control Module																																																											
J	2016	Sonic	Body	Parking Assist Control Module																																																											
J	2016	Sonic	Body	Frontview Camera Module																																																											
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module																																																											
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2016	Spin	Chassis	Electronic Brake Control Module																																																											
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Spin	Body	Body Control Module																																																										
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Spin	Body	Instrument Cluster																																																											
J	2016	Spin	Body	Radio																																																										
J	2016	Spin	Body	Telematics Communication Interface Control Module																																																											
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)																																																											
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Spin	Body	Front Seat Heating Control Module																																																											
J	2016	Spin	Body	Parking Assist Control Module																																																											
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																											
K	2006	ALL	Powertrain	Transmission Control Module																																																											
K	2006	ALL	Chassis	Electronic Brake Control Module																																																											
K	2006	ALL	Body	Remote Function Actuation																																																											
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																											
K	2007	ALL	Powertrain	Transmission Control Module																																																											
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module																																																											
K	2007	ALL	Chassis	Teves Electronic Brake Control Module																																																											
K	2007	ALL	Body	Remote Function Actuation																																																											
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																											
K	2008	ALL	Powertrain	Transmission Control Module																																																											
K	2008	ALL	Chassis	Electronic Brake Control Module																																																											
K	2008	ALL	Body	Remote Function Actuation																																																											
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																											
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																											
K	2009	ALL	Powertrain	Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2009	ALL	Chassis	Electronic Brake Control Module																																																										
K	2009	ALL	Body	Remote Function Actuation																																																										
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2010	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
K	2010	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
K	2010	ALL	Powertrain	Transmission Control Module																																																										
K	2010	ALL	Chassis	Electronic Brake Control Module																																																										
K	2010	ALL	Body	Remote Function Actuation																																																										
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2011	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
K	2011	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
K	2011	ALL	Powertrain	Transmission Control Module																																																										
K	2011	ALL	Chassis	Electronic Brake Control Module																																																										
K	2011	ALL	Body	Remote Function Actuation																																																										
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2012	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
K	2012	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
K	2012	ALL	Powertrain	Transmission Control Module																																																										
K	2012	ALL	Chassis	Electronic Brake Control Module																																																										
K	2012	ALL	Body	Remote Function Actuation																																																										
K	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2013	Onix	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
K	2013	Onix	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2013	Onix	Powertrain	Transmission Control Module																																																										
K	2013	Onix	Powertrain	Transmission Control Module																																																										
K	2013	Onix	Chassis	Electronic Brake Control Module																																																										
K	2013	Onix	Chassis	Electronic Brake Control Module																																																										
K	2013	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2013	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2013	Onix	Body	Body Control Module																																																										
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2013	Onix	Body	Instrument Cluster																																																										
K	2013	Onix	Body	Radio																																																										
K	2013	Onix	Body	Parking Assist Control Module																																																										
K	2013	Onix	Body	Remote Function Actuation																																																										
K	2013	Prisma	Powertrain	Engine Control Module																																																										
K	2013	Prisma	Powertrain	Transmission Control Module																																																										
K	2013	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2013	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2013	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2013	Prisma	Body	Body Control Module																																																										
K	2013	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2013	Prisma	Body	Instrument Cluster																																																										
K	2013	Prisma	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2013	Prisma	Body	Parking Assist Control Module																																																									
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2014	Onix	Chassis	Electronic Brake Control Module																																																										
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Onix	Body	Body Control Module																																																										
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Onix	Body	Instrument Cluster																																																										
K	2014	Onix	Body	Radio																																																										
K	2014	Onix	Body	Parking Assist Control Module																																																										
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module																																																										
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2014	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Prisma	Body	Body Control Module																																																										
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Prisma	Body	Instrument Cluster																																																										
K	2014	Prisma	Body	Radio																																																										
K	2014	Prisma	Body	Parking Assist Control Module																																																										
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2015	Onix	Chassis	Electronic Brake Control Module																																																										
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Onix	Body	Body Control Module																																																										
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Onix	Body	Instrument Cluster																																																										
K	2015	Onix	Body	Radio																																																										
K	2015	Onix	Body	Parking Assist Control Module																																																										
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																											
K	2015	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																											
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																											
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																											
K	2015	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																											
K	2015	Prisma	Chassis	Electronic Brake Control Module																																																											
K	2015	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Prisma	Body	Body Control Module																																																											
K	2015	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Prisma	Body	Instrument Cluster																																																											
K	2015	Prisma	Body	Radio																																																											
K	2015	Prisma	Body	Parking Assist Control Module																																																											
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																											
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																											
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																											
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																											
K	2016	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																											
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																											
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																											
K	2016	Onix	Powertrain	1.4L LKK Transmission Control Module																																																											
K	2016	Onix	Chassis	Electronic Brake Control Module																																																											
K	2016	Onix	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2016	Onix	Body	Body Control Module																																																											
K	2016	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2016	Onix	Body	Instrument Cluster																																																											
K	2016	Onix	Body	Radio																																																											
K	2016	Onix	Body	Parking Assist Control Module																																																											
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																											
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																											
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																											
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																											
K	2016	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																											
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																											
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																											
K	2016	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																											
K	2016	Prisma	Chassis	Electronic Brake Control Module																																																											
K	2016	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2016	Prisma	Body	Body Control Module																																																											
K	2016	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2016	Prisma	Body	Instrument Cluster																																																											
K	2016	Prisma	Body	Radio																																																											
K	2016	Prisma	Body	HVAC Control Module																																																											
K	2016	Prisma	Body	Front Seat Heating Control Module																																																											
K	2016	Prisma	Body	Parking Assist Control Module																																																											
L	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
L	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2004	ALL	Powertrain	Transmission Control Module																																																											
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																											
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																											
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2004	ALL	Body	ISU																																																										
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2005	ALL	Powertrain	Transmission Control Module																																																											
L	2005	ALL	Chassis	Anti-lock Brake System																																																											
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2005	ALL	Body	ISU																																																										
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																											
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																											
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2006	ALL	Body	ISU																																																										
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module	V	V	V	V	V	V	V	V																																																		
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																											
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																											
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector																																																											
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
L	2007	ALL	Chassis	Electronic Brake Control Module																																																											
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2007	ALL	Body	ISU																																																										
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module	V	V	V	V	V	V	V	V																																																		
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																											
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
L	2008	ALL	Chassis	Electronic Brake Control Module																																																											
L	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2008	ALL	Body	ISU																																																										
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module	V	V	V	V	V	V	V	V																																																		
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																											
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
L	2009	ALL	Chassis	Electronic Brake Control Module																																																											
L	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2009	ALL	Body	ISU																																																										
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																											
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module	V	V	V	V	V	V	V	V																																																		
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
L	2010	ALL	Chassis	Electronic Brake Control Module																																																											
L	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2010	ALL	Body	ISU																																																										
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																											
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module	V	V	V	V	V	V	V	V																																																		
L	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																										
L	2011	ALL	Chassis	Electronic Brake Control Module																																																										
L	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2011	ALL	Body	ISU																																																										
M	2004	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2004	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2004	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2004	ALL	Chassis	Anti-lock Brake System																																																										
M	2004	ALL	Body	Remote Function Actuation																																																										
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2005	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2005	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2005	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2005	ALL	Chassis	Anti-lock Brake System																																																										
M	2005	ALL	Body	Remote Function Actuation																																																										
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2006	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2006	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2006	ALL	Chassis	Anti-lock Brake System																																																										
M	2006	ALL	Body	Remote Function Actuation																																																										
M	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2007	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2007	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2007	ALL	Chassis	Anti-lock Brake System																																																										
M	2007	ALL	Body	Remote Function Actuation																																																										
M	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2008	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2008	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2008	ALL	Chassis	Anti-lock Brake System																																																										
M	2008	ALL	Body	Remote Function Actuation																																																										
M	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2009	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2009	ALL	Chassis	Anti-lock Brake System																																																										
M	2009	ALL	Body	Remote Function Actuation																																																										
M	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
M	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
M	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
M	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2010	Spark	Powertrain	Transmission Control Module																																																										
M	2010	Spark	Chassis	Electronic Brake Control Module																																																										
M	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2010	Spark	Chassis	Electric Power Steering Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
M	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2010	Spark	Body	Passenger Presence Module																																																										
M	2010	Spark	Body	Instrument Cluster																																																									
M	2011	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																									
M	2011	Caprice	Powertrain	Transmission Control Module																																																									
M	2011	Caprice	Powertrain	Fuel Pump Control Module																																																									
M	2011	Caprice	Chassis	Electronic Brake Control Module																																																									
M	2011	Caprice	Body	Body Control Module																																																									
M	2011	Caprice	Body	HVAC Control Module																																																									
M	2011	Caprice	Body	Instrument Panel Cluster																																																									
M	2011	Caprice	Body	Passenger Presence System																																																									
M	2011	Caprice	Body	Radio																																																									
M	2011	Caprice	Body	Remote Control Door Lock Receiver																																																									
M	2011	Caprice	Body	Supplemental Inflatable Restraint																																																									
M	2011	Caprice	Body	Theft Deterrent Module																																																									
M	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
M	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																									
M	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																									
M	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																									
M	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																									
M	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																									
M	2011	Spark	Powertrain	Transmission Control Module																																																									
M	2011	Spark	Chassis	Electronic Brake Control Module																																																									
M	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
M	2011	Spark	Chassis	Electric Power Steering Control Module																																																									
M	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2011	Spark	Body	Passenger Presence Module																																																									
M	2011	Spark	Body	Instrument Cluster																																																									
M	2012	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																										V																															
M	2012	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																									
M	2012	Caprice	Powertrain	Transmission Control Module																																																									
M	2012	Caprice	Powertrain	Fuel Pump Control Module																																																									
M	2012	Caprice	Chassis	Electronic Brake Control Module																																																									
M	2012	Caprice	Body	Body Control Module																																																									
M	2012	Caprice	Body	HVAC Control Module																																																									
M	2012	Caprice	Body	Instrument Panel Cluster																																																									
M	2012	Caprice	Body	Passenger Presence System																																																									
M	2012	Caprice	Body	Radio																																																									
M	2012	Caprice	Body	Remote Control Door Lock Receiver																																																									
M	2012	Caprice	Body	Supplemental Inflatable Restraint																																																									
M	2012	Caprice	Body	Theft Deterrent Module																																																									
M	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
M	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																									
M	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																									
M	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																									
M	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																									
M	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
M	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
M	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
M	2012	Spark	Powertrain	Transmission Control Module																																																										
M	2012	Spark	Chassis	Electronic Brake Control Module																																																										
M	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2012	Spark	Chassis	Electric Power Steering Control Module																																																										
M	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2012	Spark	Body	Passenger Presence Module																																																										
M	2012	Spark	Body	Instrument Cluster																																																										
M	2013	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																										V																																
M	2013	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																										
M	2013	Caprice	Powertrain	Transmission Control Module																																																										
M	2013	Caprice	Powertrain	Fuel Pump Control Module																																																										
M	2013	Caprice	Chassis	Electronic Brake Control Module																																																										
M	2013	Caprice	Body	Body Control Module																																																										
M	2013	Caprice	Body	HVAC Control Module																																																										
M	2013	Caprice	Body	Instrument Panel Cluster																																																										
M	2013	Caprice	Body	Passenger Presence System																																																										
M	2013	Caprice	Body	Radio																																																										
M	2013	Caprice	Body	Remote Control Door Lock Receiver																																																										
M	2013	Caprice	Body	Supplemental Inflatable Restraint																																																										
M	2013	Caprice	Body	Theft Deterrent Module																																																										
M	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										
M	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
M	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2013	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2013	Spark	Chassis	Electronic Brake Control Module																																																										
M	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2013	Spark	Chassis	Power Steering Control Module																																																										
M	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2013	Spark	Body	Body Control Module																																																										
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2013	Spark	Body	Passenger Presence Module																																																										
M	2013	Spark	Body	Instrument Cluster																																																										
M	2013	Spark	Body	Radio																																																										
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
M	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
M	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2014	Spark	Chassis	Power Steering Control Module																																																										
M	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2014	Spark	Body	Body Control Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Passenger Presence Module																																																										
M	2014	Spark	Body	Instrument Cluster																																																										
M	2014	Spark	Body	Radio																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark	Body	Keyless Entry Control Module																																																										
M	2014	Spark EV	Powertrain	Engine Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
M	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
M	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2014	Spark EV	Chassis	Power Steering Control Module																																																										
M	2014	Spark EV	Body	Body Control Module																																																										
M	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark EV	Body	Passenger Presence Module																																																										
M	2014	Spark EV	Body	Instrument Cluster																																																										
M	2014	Spark EV	Body	Radio																																																										
M	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
M	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2014	Spark EV	Body	Coolant Heater Control Module																																																											
M	2014	Spark EV	Body	Keyless Entry Control Module																																																											
M	2014	Spark EV	Body	Battery Charger Control Module																																																											
M	2014	Spark EV	Body	DC Charging Control Module																																																											
M	2014	Spark EV	Body	Battery Energy Control Module																																																											
M	2015	Matiz	Powertrain	1.0L LA2 Engine Control Module																																																											
M	2015	Matiz	Chassis	Electronic Brake Control Module																																																											
M	2015	Matiz	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Matiz	Body	Keyless Entry Control Module																																																											
M	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
M	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
M	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
M	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																											
M	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
M	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
M	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
M	2015	Spark	Powertrain	Fuel Injector Control Module																																																											
M	2015	Spark	Chassis	Electronic Brake Control Module																																																											
M	2015	Spark	Chassis	Electronic Brake Control Module																																																											
M	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
M	2015	Spark	Chassis	Power Steering Control Module																																																											
M	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
M	2015	Spark	Body	Body Control Module																																																											
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Spark	Body	Passenger Presence Module																																																											
M	2015	Spark	Body	Instrument Cluster																																																											
M	2015	Spark	Body	Instrument Cluster																																																											
M	2015	Spark	Body	Tire Pressure Indicator Module																																																											
M	2015	Spark	Body	Radio																																																											
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
M	2015	Spark	Body	Keyless Entry Control Module																																																											
M	2015	Spark EV	Powertrain	Engine Control Module																																																											
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
M	2015	Spark EV	Powertrain	Drive Motor Control Module																																																											
M	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
M	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2015	Spark EV	Chassis	Parking Brake Control Module																																																											
M	2015	Spark EV	Chassis	Power Steering Control Module																																																											
M	2015	Spark EV	Body	Body Control Module																																																											
M	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
M	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Spark EV	Body	Passenger Presence Module																																																												
M	2015	Spark EV	Body	Instrument Cluster																																																												
M	2015	Spark EV	Body	Radio																																																											
M	2015	Spark EV	Body	HVAC Control Module																																																											
M	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																											
M	2015	Spark EV	Body	Coolant Heater Control Module																																																											
M	2015	Spark EV	Body	Keyless Entry Control Module																																																											
M	2015	Spark EV	Body	Battery Charger Control Module																																																											
M	2015	Spark EV	Body	DC Charging Control Module																																																											
M	2015	Spark EV	Body	Battery Energy Control Module																																																											
M	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
M	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																											
M	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
M	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
M	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																											
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																											
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																											
M	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
M	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
M	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
M	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
M	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																											
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																											
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																											
M	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																											
M	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																											
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																											
M	2016	Spark	Powertrain	Fuel Injector Control Module																																																											
M	2016	Spark	Chassis	Electronic Brake Control Module																																																											
M	2016	Spark	Chassis	Electronic Brake Control Module																																																											
M	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
M	2016	Spark	Chassis	Power Steering Control Module																																																											
M	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
M	2016	Spark	Body	Body Control Module																																																											
M	2016	Spark	Body	Body Control Module																																																											
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2016	Spark	Body	Instrument Cluster																																																											
M	2016	Spark	Body	Instrument Cluster																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
M	2016	Spark	Body	Radio																																																									
M	2016	Spark	Body	Telematics Communication Interface Control Module																																																										
M	2016	Spark	Body	Keyless Entry Control Module																																																										
M	2016	Spark EV	Powertrain	Engine Control Module																																																										
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
M	2016	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
M	2016	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2016	Spark EV	Chassis	Power Steering Control Module																																																										
M	2016	Spark EV	Body	Body Control Module																																																										
M	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark EV	Body	Passenger Presence Module																																																										
M	2016	Spark EV	Body	Instrument Cluster																																																										
M	2016	Spark EV	Body	Radio																																																										
M	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
M	2016	Spark EV	Body	HVAC Control Module																																																										
M	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2016	Spark EV	Body	Coolant Heater Control Module																																																										
M	2016	Spark EV	Body	Keyless Entry Control Module																																																										
M	2016	Spark EV	Body	Frontview Camera Module																																																										
M	2016	Spark EV	Body	Battery Charger Control Module																																																										
M	2016	Spark EV	Body	DC Charging Control Module																																																										
M	2016	Spark EV	Body	Battery Energy Control Module																																																										
N	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
N	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2004	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
N	2004	Optra	Body	Remote Function Actuation																																																										
N	2004	Optra	Body	Supplemental Inflatable Restraint																																																										
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
N	2004	Classic	Chassis	Anti-lock Brake System																																																										
N	2004	Classic	Body	Body Control Module																																																										
N	2004	Classic	Body	Radio																																																										
N	2004	Classic	Body	Remote Function Actuation																																																										
N	2004	Classic	Body	Supplemental Inflatable Restraint																																																										
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																										
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Transmission Control Module																																																										
N	2004	Alero (Export)	Chassis	Anti-lock Brake System																																																										
N	2004	Alero (Export)	Body	Body Control Module																																																										
N	2004	Alero (Export)	Body	Instrument Panel Cluster																																																										
N	2004	Alero (Export)	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
N	2004	Alero (Export)	Body	Supplemental Inflatable Restraint																																																										
N	2004	Alero (Export)	Body	Vehicle Theft Deterrent																																																										
N	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																											
N	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
N	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																											
N	2005	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
N	2005	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
N	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																											
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																											
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																											
N	2005	Optra	Body	Remote Function Actuation																																																											
N	2005	Optra	Body	Supplemental Inflatable Restraint																																																											
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																											
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																											
N	2005	Classic	Chassis	Anti-lock Brake System																																																											
N	2005	Classic	Body	Body Control Module																																																										
N	2005	Classic	Body	Radio																																																										
N	2005	Classic	Body	Remote Function Actuation																																																										
N	2005	Classic	Body	Supplemental Inflatable Restraint																																																											
N	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																											
N	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
N	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
N	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																											
N	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
N	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
N	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
N	2006	ALL	Body	Remote Function Actuation																																																											
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																											
N	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
N	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
N	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																			
N	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
N	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
N	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
N	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																											
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																											
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																											
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																											
N	2007	ALL	Chassis	Tire Pressure Monitor									V	V																																																	
N	2007	ALL	Body	Remote Function Actuation																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
N	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
N	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
N	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
N	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
N	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
N	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																		
N	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																		
N	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
N	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																											
N	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
N	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
N	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
N	2008	ALL	Chassis	Tire Pressure Monitor									V	V																																																	
N	2008	ALL	Body	Remote Function Actuation																																																											
N	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
N	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
N	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
N	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
N	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
N	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																		
N	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
N	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																											
N	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
N	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
N	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
N	2009	ALL	Chassis	Tire Pressure Monitor									V	V																																																	
N	2009	ALL	Body	Remote Function Actuation																																																											
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2009	ALL	Body	Supplemental Inflatable Restraint																					V	V																																					
N	2010	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
N	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
N	2010	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
N	2010	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																		
N	2010	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
N	2010	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
N	2010	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
N	2010	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
N	2010	ALL	Chassis	Tire Pressure Monitor									V	V																																																	
N	2010	ALL	Body	Remote Function Actuation																																																											
N	2010	ALL	Body	Remote Function Actuation																																																											
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2010	ALL	Body	Supplemental Inflatable Restraint																					V	V																																					
N	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
N	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
N	2011	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2011	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																		
N	2011	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2011	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2011	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2011	ALL	Chassis	Tire Pressure Monitor									V	V																																																
N	2011	ALL	Body	Remote Function Actuation																																																										
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2011	ALL	Body	Supplemental Inflatable Restraint																					V	V																																				
N	2012	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2012	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
N	2012	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2012	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																		
N	2012	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2012	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2012	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2012	ALL	Chassis	Tire Pressure Monitor									V	V																																																
N	2012	ALL	Body	Remote Function Actuation																																																										
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2012	ALL	Body	Supplemental Inflatable Restraint																					V	V																																				
N	2013	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2013	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
N	2013	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2013	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module	V	V	V	V	V	V	V	V																																																		
N	2013	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2013	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2013	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2013	ALL	Chassis	Tire Pressure Monitor									V	V																																																
N	2013	ALL	Body	Remote Function Actuation																																																										
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2013	ALL	Body	Supplemental Inflatable Restraint																					V	V																																				
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
N	2014	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
N	2014	Caprice	Powertrain	(2) 6.0L L77 Chassis Control Module																																																										
N	2014	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
N	2014	Caprice	Chassis	Electronic Brake Control Module																																																										
N	2014	Caprice	Chassis	Parking Brake Control Module																																																										
N	2014	Caprice	Chassis	Power Steering Control Module																																																										
N	2014	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2014	Caprice	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
N	2014	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2014	Caprice	Body	Passenger Presence Module																																																											
N	2014	Caprice	Body	Instrument Cluster																																																											
N	2014	Caprice	Body	Radio Controls																																																											
N	2014	Caprice	Body	HVAC Controls																																																											
N	2014	Caprice	Body	Headlamp Control Module																																																											
N	2014	Caprice	Body	Trailer Interface Control Module																																																											
N	2014	Caprice	Body	Radio																																																											
N	2014	Caprice	Body	HVAC Control Module																																																											
N	2014	Caprice	Body	Parking Assist Control Module																																																											
N	2014	Caprice	Body	Frontview Camera Module																																																											
N	2014	Caprice	Body	Steering Column Lock Control Module																																																											
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
N	2015	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																											
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																											
N	2015	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																											
N	2015	Caprice	Powertrain	Fuel Injector Control Module																																																											
N	2015	Caprice	Chassis	Electronic Brake Control Module																																																											
N	2015	Caprice	Chassis	Parking Brake Control Module																																																											
N	2015	Caprice	Chassis	Power Steering Control Module																																																											
N	2015	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2015	Caprice	Chassis	Suspension Control Module																																																											
N	2015	Caprice	Body	Body Control Module																																																											
N	2015	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2015	Caprice	Body	Passenger Presence Module																																																											
N	2015	Caprice	Body	Instrument Cluster																																																											
N	2015	Caprice	Body	Head-Up Display Module																																																											
N	2015	Caprice	Body	Radio Controls																																																											
N	2015	Caprice	Body	HVAC Controls																																																											
N	2015	Caprice	Body	Headlamp Control Module																																																											
N	2015	Caprice	Body	Trailer Interface Control Module																																																											
N	2015	Caprice	Body	Radio																																																											
N	2015	Caprice	Body	Telematics Communication Interface Control Module																																																											
N	2015	Caprice	Body	HVAC Control Module																																																											
N	2015	Caprice	Body	Right Side Object Detection Control Module																																																											
N	2015	Caprice	Body	Left Side Object Detection Control Module																																																											
N	2015	Caprice	Body	Parking Assist Control Module																																																											
N	2015	Caprice	Body	Frontview Camera Module																																																											
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
N	2016	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																											
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																											
N	2016	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																											
N	2016	Caprice	Powertrain	Fuel Injector Control Module																																																											
N	2016	Caprice	Chassis	Electronic Brake Control Module																																																											
N	2016	Caprice	Chassis	Parking Brake Control Module																																																											
N	2016	Caprice	Chassis	Power Steering Control Module																																																											
N	2016	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
N	2016	Caprice	Chassis	Suspension Control Module																																																									
N	2016	Caprice	Body	Body Control Module																																																									
N	2016	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2016	Caprice	Body	Passenger Presence Module																																																									
N	2016	Caprice	Body	Instrument Cluster																																																									
N	2016	Caprice	Body	Head-Up Display Module																																																									
N	2016	Caprice	Body	Radio Controls																																																									
N	2016	Caprice	Body	HVAC Controls																																																									
N	2016	Caprice	Body	Trailer Interface Control Module																																																									
N	2016	Caprice	Body	Radio																																																									
N	2016	Caprice	Body	Telematics Communication Interface Control Module																																																									
N	2016	Caprice	Body	HVAC Control Module																																																									
N	2016	Caprice	Body	Seat Memory Control Module - Driver																																																									
N	2016	Caprice	Body	Right Side Object Detection Control Module																																																									
N	2016	Caprice	Body	Left Side Object Detection Control Module																																																									
N	2016	Caprice	Body	Parking Assist Control Module																																																									
N	2016	Caprice	Body	Frontview Camera Module																																																									
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																													
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission											V	V																																													
P	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																									
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission													V	V																																										
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission													V	V																																										
P	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																									
P	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission													V	V																																										
P	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission													V	V																																										
P	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission															V	V	V	V	V																																					
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission															V	V	V	V	V																																					
P	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																									
P	2010	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2010	Cruze	Body	Body Control Module																				V																																					
P	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2010	Cruze	Body	Passenger Presence Module																																																									
P	2010	Cruze	Body	Instrument Cluster																																																									
P	2010	Cruze	Body	Trailer Interface Control Module																																																									
P	2010	Cruze	Body	Radio																																																									
P	2010	Cruze	Body	Multimedia Player Interface Module																																																									
P	2010	Cruze	Body	Mobile Telephone Control Module																																																									
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
P	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
P	2010	Cruze	Body	Keyless Entry Control Module																																																									
P	2010	Cruze	Body	Parking Assist Control Module																																																									
P	2010	Cruze	Body	Steering Column Lock Control Module																																																									
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																	
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																	
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																									
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission											V	V																																													
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission											V	V																																													
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission													V	V																																										
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission													V	V																																										
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission												V												V	V																																
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission												V												V																																
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																									
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																													
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission											V	V																																													
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission													V	V																																										
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission													V	V																																										
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission												V												V	V																																
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission												V												V																																
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission											V												V	V																																	
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission											V													V																																	
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																									
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission															V	V	V	V	V																																					
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission															V	V	V	V	V																																					
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																									
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V																		
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V																		
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2011	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2011	Cruze	Body	Body Control Module																				V																																					
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2011	Cruze	Body	Passenger Presence Module																																																									
P	2011	Cruze	Body	Instrument Cluster																																																									
P	2011	Cruze	Body	Trailer Interface Control Module																																																									
P	2011	Cruze	Body	Radio																																																									
P	2011	Cruze	Body	Multimedia Player Interface Module																																																									
P	2011	Cruze	Body	Mobile Telephone Control Module																																																									
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
P	2011	Cruze	Body	Keyless Entry Control Module																																																									
P	2011	Cruze	Body	Parking Assist Control Module																																																									
P	2011	Cruze	Body	Steering Column Lock Control Module																																																									
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																	
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																	
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																									
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission											V	V																																													
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission											V	V																																													

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
P	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission													V	V																																											
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission													V	V																																											
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission												V													V	V																															
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission												V													V																															
P	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																									
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																													
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission											V	V																																													
P	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V			V	V																													
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V			V	V																													
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission													V	V																																										
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission													V	V																																										
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission												V													V	V																															
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission												V													V																															
P	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission											V	V							V							V													V	V																	
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission											V	V							V																				V	V																	
P	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission											V													V	V																																	
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission											V														V																																	
P	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission															V	V	V	V	V																																						
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission															V	V	V	V	V																																						
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V	V			V																
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V	V			V																
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																									
P	2012	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2012	Cruze	Body	Body Control Module Hatchback																				V																																					
P	2012	Cruze	Body	Body Control Module Sedan																				V																																					
P	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2012	Cruze	Body	Passenger Presence Module																																																									
P	2012	Cruze	Body	Instrument Cluster																																																									
P	2012	Cruze	Body	Trailer Interface Control Module																																																									
P	2012	Cruze	Body	Radio																																																									
P	2012	Cruze	Body	Multimedia Player Interface Module																																																									
P	2012	Cruze	Body	Mobile Telephone Control Module																																																									
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
P	2012	Cruze	Body	Keyless Entry Control Module																																																									
P	2012	Cruze	Body	Parking Assist Control Module																																																									
P	2012	Cruze	Body	Steering Column Lock Control Module																																																									
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission												V													V	V																															
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission												V													V																																	
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission											V											V	V	V																																	

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																		
P	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																											
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission											V												V	V	V																																		
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission											V												V	V	V																																		
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission											V	V																																														
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission											V	V																																														
P	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission													V	V																																											
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission													V	V																																											
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission											V	V	V												V	V																																
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission											V	V	V												V																																	
P	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																														
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission											V	V																																														
P	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V			V	V																															
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V			V	V																															
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																											
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission													V	V																																											
P	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission											V	V	V												V	V																																
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission											V	V	V												V																																	
P	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission											V												V	V	V																																		
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission											V												V	V	V																																		
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission											V												V	V	V																																		
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission											V												V	V	V																																		
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V	V			V																
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V																
P	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2013	Cruze	Chassis	Electronic Brake Control Module																																																										
P	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2013	Cruze	Body	Body Control Module Hatchback																				V																							V															
P	2013	Cruze	Body	Body Control Module Sedan																				V																							V															
P	2013	Cruze	Body	Body Control Module Station Wagon																				V																							V															
P	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2013	Cruze	Body	Passenger Presence Module																																																										
P	2013	Cruze	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
P	2013	Cruze	Body	Trailer Interface Control Module																																																									
P	2013	Cruze	Body	Radio																																																									
P	2013	Cruze	Body	Digital Radio Receiver Control Module																																																									
P	2013	Cruze	Body	Multimedia Player Interface Module																																																									
P	2013	Cruze	Body	Mobile Telephone Control Module																																																									
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																													V											
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																													V											
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																													V											
P	2013	Cruze	Body	Front Seat Heating Control Module																																																									
P	2013	Cruze	Body	Keyless Entry Control Module																																																									
P	2013	Cruze	Body	Right Side Object Detection Control Module																																																									
P	2013	Cruze	Body	Left Side Object Detection Control Module																																																									
P	2013	Cruze	Body	Parking Assist Control Module																																																									
P	2013	Cruze	Body	Steering Column Lock Control Module																																																									
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission											V												V	V	V																																
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission											V												V	V	V																																
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission											V												V	V	V																																
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission											V												V	V	V																																
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission											V	V																																													
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission											V	V																																													
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission													V	V																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission													V	V																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission											V	V	V												V	V																															
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission											V	V	V												V																																
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission											V													V	V																																
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission											V													V	V																																
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																									
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																												
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission											V	V																																												
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																								V			V	V																				V								
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																								V			V	V																				V								
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V			V	V																												
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V			V	V																												
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																									
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission													V	V																																									
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission											V	V	V												V	V																																
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission											V	V	V												V																																	
P	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission											V												V	V	V																																	
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission											V												V	V	V																																	
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																									
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission											V												V	V	V																																	
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission											V												V	V	V																																	
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																									
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V				V															
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V				V															
P	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																											V							V	V	V	V								V		V	V	V	V	V	V	V	V	V
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																									
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																												V																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																									
P	2014	Cruze	Powertrain	Fuel Injector Control Module																																																									
P	2014	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2014	Cruze	Chassis	Power Steering Control Module																																																									
P	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2014	Cruze	Body	Body Control Module Hatchback																				V																								V													
P	2014	Cruze	Body	Body Control Module Sedan																				V																								V													
P	2014	Cruze	Body	Body Control Module Station Wagon																				V																								V													
P	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2014	Cruze	Body	Passenger Presence Module																																																									
P	2014	Cruze	Body	Instrument Cluster																																																									
P	2014	Cruze	Body	Trailer Interface Control Module																																																									
P	2014	Cruze	Body	Radio																																																									
P	2014	Cruze	Body	Digital Radio Receiver Control Module																																																									
P	2014	Cruze	Body	Multimedia Player Interface Module																																																									
P	2014	Cruze	Body	Mobile Telephone Control Module																																																									
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																												V													
P	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																												V													
P	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																												V													
P	2014	Cruze	Body	Front Seat Heating Control Module																																																									
P	2014	Cruze	Body	Keyless Entry Control Module																																																									
P	2014	Cruze	Body	Right Side Object Detection Control Module																																																									
P	2014	Cruze	Body	Left Side Object Detection Control Module																																																									
P	2014	Cruze	Body	Parking Assist Control Module																																																									
P	2014	Cruze	Body	Steering Column Lock Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission											V												V	V	V																																
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission											V												V	V	V																																
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission											V												V	V	V																																
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission											V												V	V	V																																
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission											V	V																																												
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission											V	V																																												
P	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission													V	V																																									
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission													V	V																																									
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission											V	V	V												V	V																															
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission											V	V	V												V																															
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission											V													V	V																																
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission											V													V	V																																
P	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																												
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission											V	V																																												
P	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																								V		V	V																				V									
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																								V		V	V																				V									
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V		V	V																													
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V		V	V																													
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																									
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission													V	V																																									
P	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission											V	V	V												V	V																														
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission											V	V	V												V																															
P	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission											V												V	V	V																																
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission											V												V	V	V																																
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission											V												V	V	V																																
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission											V												V	V	V																																

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																									
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V																
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V																
P	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																											V								V	V	V	V								V		V	V	V	V	V	V	V	V	V
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																									
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																									
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																												V																													
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																									
P	2015	Cruze	Powertrain	Fuel Injector Control Module																																																									
P	2015	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2015	Cruze	Chassis	Power Steering Control Module																																																									
P	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2015	Cruze	Body	Body Control Module Hatchback																				V																								V													
P	2015	Cruze	Body	Body Control Module Sedan																				V																								V													
P	2015	Cruze	Body	Body Control Module Station Wagon																				V																								V													
P	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2015	Cruze	Body	Passenger Presence Module																																																									
P	2015	Cruze	Body	Instrument Cluster																																																									
P	2015	Cruze	Body	Trailer Interface Control Module																																																									
P	2015	Cruze	Body	Radio																																																									
P	2015	Cruze	Body	Digital Radio Receiver Control Module																																																									
P	2015	Cruze	Body	Multimedia Player Interface Module																																																									
P	2015	Cruze	Body	Mobile Telephone Control Module																																																									
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																												V													
P	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																												V													
P	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																												V													
P	2015	Cruze	Body	Front Seat Heating Control Module																																																									
P	2015	Cruze	Body	Keyless Entry Control Module																																																									
P	2015	Cruze	Body	Right Side Object Detection Control Module																																																									
P	2015	Cruze	Body	Left Side Object Detection Control Module																																																									
P	2015	Cruze	Body	Parking Assist Control Module																																																									
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																
P	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																									
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission											V												V	V	V																																
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission											V												V	V	V																																
P	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission											V	V																																												
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission											V	V																																												
P	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission													V	V																																									
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission													V	V																																									
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission											V	V													V	V																															

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission											V	V													V																															
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission											V	V																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission											V	V																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																										
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission													V	V																																										
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission											V	V													V	V																															
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission											V	V													V																																
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission											V												V	V	V																																
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission											V												V	V	V																																
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission											V												V	V	V																																
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission											V												V	V	V																																
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																	
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2016	Cruze	Powertrain	Fuel Injector Control Module																																																								
P	2016	Cruze	Powertrain	Chassis Control Module																																																								
P	2016	Cruze	Chassis	Electronic Brake Control Module																																																								
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2016	Cruze	Chassis	Power Steering Control Module																																																								
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2016	Cruze	Body	Body Control Module Hatchback																																																								
P	2016	Cruze	Body	Body Control Module Sedan																																																								
P	2016	Cruze	Body	Body Control Module Station Wagon																																																								
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2016	Cruze	Body	Passenger Presence Module																																																								
P	2016	Cruze	Body	Instrument Cluster																																																								
P	2016	Cruze	Body	Trailer Interface Control Module																																																								
P	2016	Cruze	Body	Radio Other																																																								
P	2016	Cruze	Body	Radio (UF7)																																																								
P	2016	Cruze	Body	Multimedia Player Interface Module																																																								
P	2016	Cruze	Body	Mobile Telephone Control Module																																																								
P	2016	Cruze	Body	Telematics Communication Interface Control Module																																																								
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																								
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																								
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																								
P	2016	Cruze	Body	Front Seat Heating Control Module																																																								
P	2016	Cruze	Body	Keyless Entry Control Module																																																								
P	2016	Cruze	Body	Right Side Object Detection Control Module																																																								
P	2016	Cruze	Body	Left Side Object Detection Control Module																																																								
P	2016	Cruze	Body	Parking Assist Control Module																																																								
P	2016	Cruze	Body	Steering Column Lock Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2011	Volt	Powertrain	Engine Control Module																																																										
R	2011	Volt	Powertrain	Trasmission Control Module																																																											
R	2011	Volt	Powertrain	Fuel Pump Control Module																																																											
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module																																																											
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2011	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2011	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2011	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2011	Volt	Chassis	Electronic Brake Control Module																																																											
R	2011	Volt	Chassis	Parking Brake Control Module																																																											
R	2011	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
R	2011	Volt	Chassis	Power Steering Control Module																																																											
R	2011	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2011	Volt	Body	Body Control Module																																																											
R	2011	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2011	Volt	Body	Passenger Presence Module																																																											
R	2011	Volt	Body	Instrument Cluster																																																											
R	2011	Volt	Body	Radio																																																											
R	2011	Volt	Body	Digital Radio Receiver Control Module																																																											
R	2011	Volt	Body	Mobile Telephone Control Module																																																											
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2011	Volt	Body	Remote Heater and Air Conditioning Control Module																																																											
R	2011	Volt	Body	Electric A/C Compressor Control Module																																																											
R	2011	Volt	Body	Coolant Heater Control Module																																																											
R	2011	Volt	Body	Keyless Entry Control Module																																																											
R	2011	Volt	Body	Parking Assist Control Module																																																											
R	2011	Volt	Body	Steering Column Lock Control Module																																																											
R	2011	Volt	Body	Battery Charger Control Module																																																											
R	2011	Volt	Body	Battery Energy Control Module																																																											
R	2012	Volt	Powertrain	Engine Control Module																																																											
R	2012	Volt	Powertrain	Trasmission Control Module																																																											
R	2012	Volt	Powertrain	Fuel Pump Control Module																																																											
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module																																																											
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2012	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2012	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2012	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2012	Volt	Chassis	Electronic Brake Control Module																																																											
R	2012	Volt	Chassis	Parking Brake Control Module																																																											
R	2012	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
R	2012	Volt	Chassis	Power Steering Control Module																																																											
R	2012	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2012	Volt	Body	Body Control Module																																																											
R	2012	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2012	Volt	Body	Passenger Presence Module																																																											
R	2012	Volt	Body	Instrument Cluster																																																											
R	2012	Volt	Body	Radio																																																											
R	2012	Volt	Body	Digital Radio Receiver Control Module																																																											
R	2012	Volt	Body	Mobile Telephone Control Module																																																											
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 9																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2012	Volt	Body	Remote Heater and Air Conditioning Control Module																																																										
R	2012	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2012	Volt	Body	Coolant Heater Control Module																																																										
R	2012	Volt	Body	Keyless Entry Control Module																																																										
R	2012	Volt	Body	Parking Assist Control Module																																																										
R	2012	Volt	Body	Steering Column Lock Control Module																																																										
R	2012	Volt	Body	Battery Charger Control Module																																																										
R	2012	Volt	Body	Battery Energy Control Module																																																										
R	2013	Volt	Powertrain	Engine Control Module																																																										
R	2013	Volt	Powertrain	Trasmission Control Module																																																										
R	2013	Volt	Powertrain	Fuel Pump Control Module																																																										
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2013	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2013	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2013	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2013	Volt	Chassis	Electronic Brake Control Module																																																										
R	2013	Volt	Chassis	Parking Brake Control Module																																																										
R	2013	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
R	2013	Volt	Chassis	Power Steering Control Module																																																										
R	2013	Volt	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2013	Volt	Body	Body Control Module																																																										
R	2013	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2013	Volt	Body	Passenger Presence Module																																																										
R	2013	Volt	Body	Instrument Cluster																																																										
R	2013	Volt	Body	Radio																																																										
R	2013	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2013	Volt	Body	Multimedia Player Interface Module																																																										
R	2013	Volt	Body	Mobile Telephone Control Module																																																										
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2013	Volt	Body	HVAC Control Module																																																										
R	2013	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2013	Volt	Body	Coolant Heater Control Module																																																										
R	2013	Volt	Body	Front Seat Heating Control Module																																																										
R	2013	Volt	Body	Keyless Entry Control Module																																																										
R	2013	Volt	Body	Parking Assist Control Module																																																										
R	2013	Volt	Body	Frontview Camera Module																																																										
R	2013	Volt	Body	Steering Column Lock Control Module																																																										
R	2013	Volt	Body	Battery Charger Control Module																																																										
R	2013	Volt	Body	Battery Energy Control Module																																																										
R	2014	Volt	Powertrain	Engine Control Module																																																										
R	2014	Volt	Powertrain	Trasmission Control Module																																																										
R	2014	Volt	Powertrain	Chassis Control Module																																																										
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2014	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2014	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2014	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2014	Volt	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2014	Volt	Chassis	Parking Brake Control Module																																																									
R	2014	Volt	Chassis	Power Steering Control Module																																																										
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2014	Volt	Body	Body Control Module																																																										
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2014	Volt	Body	Passenger Presence Module																																																										
R	2014	Volt	Body	Instrument Cluster																																																										
R	2014	Volt	Body	Radio																																																										
R	2014	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	Volt	Body	HVAC Control Module																																																										
R	2014	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2014	Volt	Body	Coolant Heater Control Module																																																										
R	2014	Volt	Body	Front Seat Heating Control Module																																																										
R	2014	Volt	Body	Keyless Entry Control Module																																																										
R	2014	Volt	Body	Parking Assist Control Module																																																										
R	2014	Volt	Body	Frontview Camera Module																																																										
R	2014	Volt	Body	Steering Column Lock Control Module																																																										
R	2014	Volt	Body	Battery Charger Control Module																																																										
R	2014	Volt	Body	Battery Energy Control Module																																																										
R	2015	Volt	Powertrain	Engine Control Module																																																										
R	2015	Volt	Powertrain	Trasmission Control Module																																																										
R	2015	Volt	Powertrain	Chassis Control Module																																																										
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2015	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2015	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																										
R	2015	Volt	Chassis	Electronic Brake Control Module																																																										
R	2015	Volt	Chassis	Parking Brake Control Module																																																										
R	2015	Volt	Chassis	Power Steering Control Module																																																										
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module																																																										
R	2015	Volt	Body	Body Control Module																																																										
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	Volt	Body	Passenger Presence Module																																																										
R	2015	Volt	Body	Instrument Cluster																																																										
R	2015	Volt	Body	Radio																																																										
R	2015	Volt	Body	Digital Radio Receiver Control Module																																																										
R	2015	Volt	Body	Telematics Communication Interface Control Module																																																										
R	2015	Volt	Body	HVAC Control Module																																																										
R	2015	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2015	Volt	Body	Coolant Heater Control Module																																																										
R	2015	Volt	Body	Front Seat Heating Control Module																																																										
R	2015	Volt	Body	Keyless Entry Control Module																																																										
R	2015	Volt	Body	Parking Assist Control Module																																																										
R	2015	Volt	Body	Frontview Camera Module																																																										
R	2015	Volt	Body	Steering Column Lock Control Module																																																										
R	2015	Volt	Body	Battery Charger Control Module																																																										
R	2015	Volt	Body	Battery Energy Control Module																																																										
R	2016	Volt	Powertrain	Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module																																																										
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																										
R	2016	Volt	Powertrain	Drive Motor Control Module 1																																																										
R	2016	Volt	Powertrain	Drive Motor Control Module 2																																																										
R	2016	Volt	Chassis	Electronic Brake Control Module																																																										
R	2016	Volt	Chassis	Brake Booster Control Module																																																										
R	2016	Volt	Chassis	Power Steering Control Module																																																										
R	2016	Volt	Body	Body Control Module																																																										
R	2016	Volt	Body	Pedestrian Alert Sound Control Module																																																										
R	2016	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Volt	Body	Passenger Presence Module																																																										
R	2016	Volt	Body	Instrument Cluster																																																										
R	2016	Volt	Body	Radio Controls																																																										
R	2016	Volt	Body	HVAC Controls																																																										
R	2016	Volt	Body	Radio																																																										
R	2016	Volt	Body	Amplifier																																																										
R	2016	Volt	Body	Human Machine Interface Control Module																																																										
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 9.7																																																										
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2016	Volt	Body	HVAC Control Module																																																										
R	2016	Volt	Body	Electric A/C Compressor Control Module																																																										
R	2016	Volt	Body	Keyless Entry Control Module																																																										
R	2016	Volt	Body	Right Side Object Detection Control Module																																																										
R	2016	Volt	Body	Left Side Object Detection Control Module																																																										
R	2016	Volt	Body	Parking Assist Control Module																																																										
R	2016	Volt	Body	Frontview Camera Module																																																										
R	2016	Volt	Body	Steering Column Lock Control Module																																																										
R	2016	Volt	Body	Battery Energy Control Module																																																										
R	2016	Volt	Body	Long Range Radar Sensor Module																																																										
S	2004	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2004	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2004	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2004	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
S	2004	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2004	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
S	2004	Aveo	Powertrain	Transmission Control Module																																																										
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2004	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2004	Aveo	Body	Remote Function Actuation																																																										
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2005	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2005	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2005	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
S	2005	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2005	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
S	2005	Aveo	Powertrain	Transmission Control Module																																																										
S	2005	Aveo	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2005	Aveo	Body	Supplemental Inflatable Restraint																																																									
S	2005	Aveo	Body	Remote Function Actuation																																																									
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2006	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
S	2006	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
S	2006	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
S	2006	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2006	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2006	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2006	Aveo	Body	Remote Function Actuation																																																										
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2007	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
S	2007	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
S	2007	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
S	2007	Aveo	Powertrain	Transmission Control Module 4 Speed																																																										
S	2007	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2007	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2007	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2007	Aveo	Body	Remote Function Actuation																																																										
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2008	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2008	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
S	2008	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2008	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2008	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
S	2008	Aveo	Powertrain	Transmission Control Module																																																										
S	2008	Aveo	Powertrain	Transmission Control Module																																																										
S	2008	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2008	Aveo	Chassis	Tire Pressure Monitor									V	V																																															
S	2008	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2008	Aveo	Body	Remote Function Actuation																																																										
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																										
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																										
S	2009	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
S	2009	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2009	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2009	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																												
S	2009	Aveo	Powertrain	Transmission Control Module																																																													
S	2009	Aveo	Powertrain	Transmission Control Module																																																												
S	2009	Aveo	Powertrain	Other Auto Transmission System																																																												
S	2009	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2009	Aveo	Chassis	Tire Pressure Monitor									V	V																																																	
S	2009	Aveo	Body	Supplemental Inflatable Restraint																																																												
S	2009	Aveo	Body	Remote Function Actuation																																																												
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																												
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																												
S	2010	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
S	2010	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
S	2010	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																												
S	2010	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
S	2010	Aveo	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																												
S	2010	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																												
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2010	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2010	Aveo	Chassis	Tire Pressure Monitor									V	V																																																	
S	2010	Aveo	Body	Supplemental Inflatable Restraint																																																												
S	2010	Aveo	Body	Remote Function Actuation																																																												
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																												
S	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																												
S	2010	Sail	Powertrain	Transmission Control Module																																																												
S	2010	Sail	Chassis	Electronic Brake Control Module																																																												
S	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																												
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																												
S	2011	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
S	2011	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
S	2011	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																												
S	2011	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
S	2011	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																												
S	2011	Aveo	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																												
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2011	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2011	Aveo	Chassis	Tire Pressure Monitor									V	V																																																	
S	2011	Aveo	Body	Supplemental Inflatable Restraint																																																												
S	2011	Aveo	Body	Remote Function Actuation																																																												
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																												
S	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																												
S	2011	Sail	Powertrain	Transmission Control Module																																																												
S	2011	Sail	Chassis	Electronic Brake Control Module																																																												
S	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																										
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																											
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																											
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																											
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
S	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
S	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																											
S	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
S	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																											
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																											
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
S	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
S	2012	Aveo	Powertrain	Fuel Pump Control Module																																																											
S	2012	Aveo	Powertrain	Fuel Injector Control Module																																																											
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2012	Aveo	Chassis	Electric Power Steering Control Module																																																											
S	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2012	Aveo	Chassis	Tire Pressure Monitor									V	V																																																
S	2012	Aveo	Body	Body Control Module Hatchback																																																											
S	2012	Aveo	Body	Body Control Module Sedan																																																											
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2012	Aveo	Body	Passenger Presence Module																																																											
S	2012	Aveo	Body	Instrument Cluster																																																											
S	2012	Aveo	Body	Radio																																																										
S	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																											
S	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
S	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
S	2012	Aveo	Body	Front Seat Heating Control Module																																																											
S	2012	Aveo	Body	Remote Function Actuation																																																											
S	2012	Aveo	Body	Parking Assist Control Module																																																											
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																									
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																										
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																										
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2012	Sail	Powertrain	Transmission Control Module																																																										
S	2012	Sail	Chassis	Electronic Brake Control Module																																																										
S	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
S	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
S	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
S	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
S	2013	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2013	Aveo	Powertrain	Fuel Pump Control Module																																																										
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2013	Aveo	Chassis	Electric Power Steering Control Module																																																										
S	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2013	Aveo	Body	Body Control Module Hatchback																																																										
S	2013	Aveo	Body	Body Control Module Sedan																																																										
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Aveo	Body	Passenger Presence Module																																																										
S	2013	Aveo	Body	Instrument Cluster																																																										
S	2013	Aveo	Body	Radio																																																										
S	2013	Aveo	Body	Telematics Communication Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2013	Aveo	Body	Front Seat Heating Control Module																																																										
S	2013	Aveo	Body	Remote Function Actuation																																																										
S	2013	Aveo	Body	Parking Assist Control Module																																																										
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2013	Sail	Powertrain	Transmission Control Module																																																										
S	2013	Sail	Chassis	Electronic Brake Control Module																																																										
S	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																												V	V													
S	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																												V	V													
S	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
S	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																												V	V													
S	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
S	2014	Aveo	Powertrain	Chassis Control Module																																																										
S	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2014	Aveo	Chassis	Power Steering Control Module																																																										
S	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2014	Aveo	Body	Body Control Module Hatchback																																																										
S	2014	Aveo	Body	Body Control Module Sedan																																																										
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Aveo	Body	Instrument Cluster																																																										
S	2014	Aveo	Body	Radio																																																										
S	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
S	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2014	Aveo	Body	Front Seat Heating Control Module																																																										
S	2014	Aveo	Body	Keyless Entry Control Module																																																										
S	2014	Aveo	Body	Parking Assist Control Module																																																										
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2014	Sail	Powertrain	Transmission Control Module																																																										
S	2014	Sail	Chassis	Electronic Brake Control Module																																																										
S	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																													V	V												
S	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
S	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																													V	V												
S	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																											
S	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																													V	V												
S	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
S	2015	Aveo	Powertrain	Chassis Control Module																																																												
S	2015	Aveo	Powertrain	Fuel Injector Control Module																																																												
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2015	Aveo	Chassis	Power Steering Control Module																																																												
S	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2015	Aveo	Body	Body Control Module Hatchback																																																												
S	2015	Aveo	Body	Body Control Module Sedan																																																												
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2015	Aveo	Body	Instrument Cluster																																																											
S	2015	Aveo	Body	Radio																																																										
S	2015	Aveo	Body	Telematics Communication Interface Control Module																																																											
S	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
S	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
S	2015	Aveo	Body	Front Seat Heating Control Module																																																											
S	2015	Aveo	Body	Keyless Entry Control Module																																																											
S	2015	Aveo	Body	Parking Assist Control Module																																																											
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
S	2015	Sail	Powertrain	Transmission Control Module																																																											
S	2015	Sail	Chassis	Electronic Brake Control Module																																																											
S	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
S	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																													V	V											
S	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																											
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
S	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
S	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
S	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
S	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																												V	V											
S	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																											
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
S	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
S	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
S	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																											
S	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																												V	V											
S	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
S	2016	Aveo	Powertrain	Chassis Control Module																																																											
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2016	Aveo	Chassis	Power Steering Control Module																																																											
S	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2016	Aveo	Body	Body Control Module Hatchback																																																											
S	2016	Aveo	Body	Body Control Module Sedan																																																											
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2016	Aveo	Body	Instrument Cluster																																																											
S	2016	Aveo	Body	Radio																																																											
S	2016	Aveo	Body	Telematics Communication Interface Control Module																																																											
S	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
S	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
S	2016	Aveo	Body	Front Seat Heating Control Module																																																											
S	2016	Aveo	Body	Parking Assist Control Module																																																											
S	2016	Aveo	Body	Keyless Entry Control Module																																																											
S	2016	Aveo	Body	Frontview Camera Module																																																											
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																										
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2016	Sail	Powertrain	Transmission Control Module																																																										
S	2016	Sail	Chassis	Electronic Brake Control Module																																																										
S	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2004	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2004	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2004	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
T	2004	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2004	ALL	Powertrain	Transmission Control Module																																																										
T	2004	ALL	Chassis	Electronic Brake Control Module																																																										
T	2004	ALL	Chassis	Electronic Brake Control Module																																																										
T	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2004	ALL	Body	Remote Function Actuation																																																										
T	2005	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2005	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2005	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
T	2005	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2005	ALL	Powertrain	Transmission Control Module																																																										
T	2005	ALL	Chassis	Electronic Brake Control Module																																																										
T	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2005	ALL	Body	Remote Function Actuation																																																										
T	2006	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
T	2006	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
T	2006	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
T	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2006	ALL	Chassis	Electronic Brake Control Module																																																										
T	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2006	ALL	Body	Remote Function Actuation																																																										
T	2007	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
T	2007	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
T	2007	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
T	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
T	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2007	ALL	Chassis	Electronic Brake Control Module																																																										
T	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2007	ALL	Body	Remote Function Actuation																																																										
T	2008	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
T	2008	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2008	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
T	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
T	2008	ALL	Powertrain	Transmission Control Module																																																										
T	2008	ALL	Powertrain	Transmission Control Module																																																										
T	2008	ALL	Chassis	Electronic Brake Control Module																																																										
T	2008	ALL	Chassis	Tire Pressure Monitor									V	V																																																
T	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2008	ALL	Body	Remote Function Actuation																																																										
T	2008	ALL	Body	Passenger Presence System																																																										
T	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
T	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
T	2009	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
T	2009	ALL	Powertrain	Transmission Control Module																																																										
T	2009	ALL	Powertrain	Transmission Control Module																																																										
T	2009	ALL	Chassis	Electronic Brake Control Module																																																										
T	2009	ALL	Chassis	Tire Pressure Monitor									V	V																																																
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2009	ALL	Body	Instrument Panel Cluster																																																										
T	2009	ALL	Body	Passenger Presence System																																																										
T	2009	ALL	Body	Theft Deterrent Module																																																										
T	2009	ALL	Body	Radio																																																										
T	2009	ALL	Body	Remote Function Actuation																																																										
T	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																										
T	2010	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2010	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
T	2010	ALL	Powertrain	Transmission Control Module																																																										
T	2010	ALL	Powertrain	Transmission Control Module																																																										
T	2010	ALL	Chassis	Electronic Brake Control Module																																																										
T	2010	ALL	Chassis	Tire Pressure Monitor									V	V																																																
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Instrument Panel Cluster																																																										
T	2010	ALL	Body	Passenger Presence System																																																										
T	2010	ALL	Body	Theft Deterrent Module																																																										
T	2010	ALL	Body	Radio																																																										
T	2010	ALL	Body	Remote Function Actuation																																																										
T	2011	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
T	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2011	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2011	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module Argentia																																																										
T	2011	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																										
T	2011	ALL	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																										
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2011	ALL	Chassis	Electronic Brake Control Module																																																										
T	2011	ALL	Chassis	Tire Pressure Monitor									V	V																																																

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2011	ALL	Body	Instrument Panel Cluster																																																										
T	2011	ALL	Body	Passenger Presence System																																																										
T	2011	ALL	Body	Theft Deterrent Module																																																										
T	2011	ALL	Body	Radio																																																										
T	2011	ALL	Body	Remote Function Actuation																																																										
T	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																										
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																										
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
T	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																										
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																										
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																										
T	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
T	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																										
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
T	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
T	2012	Aveo	Powertrain	Fuel Injector Control Module																																																										
T	2012	Aveo	Powertrain	Fuel Pump Control Module																																																										
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2012	Aveo	Chassis	Electric Power Steering Control Module																																																										
T	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2012	Aveo	Chassis	Tire Pressure Monitor									V	V																																															
T	2012	Aveo	Body	Body Control Module Hatchback																																																										
T	2012	Aveo	Body	Body Control Module Sedan																																																										
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2012	Aveo	Body	Passenger Presence Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2012	Aveo	Body	Instrument Cluster																																																										
T	2012	Aveo	Body	Radio																																																										
T	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																											
T	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
T	2012	Aveo	Body	Front Seat Heating Control Module																																																											
T	2012	Aveo	Body	Remote Function Actuation																																																											
T	2012	Aveo	Body	Parking Assist Control Module																																																											
T	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																											
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
T	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
T	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																											
T	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
T	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
T	2013	Aveo	Powertrain	Fuel Injector Control Module																																																											
T	2013	Aveo	Powertrain	Fuel Pump Control Module																																																											
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2013	Aveo	Chassis	Electric Power Steering Control Module																																																											
T	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2013	Aveo	Body	Body Control Module Hatchback																																																											
T	2013	Aveo	Body	Body Control Module Sedan																																																											
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	Aveo	Body	Passenger Presence Module																																																											
T	2013	Aveo	Body	Instrument Cluster																																																											
T	2013	Aveo	Body	Radio																																																											
T	2013	Aveo	Body	Telematics Communication Interface Control Module																																																											
T	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2013	Aveo	Body	Front Seat Heating Control Module																																																									
T	2013	Aveo	Body	Remote Function Actuation																																																									
T	2013	Aveo	Body	Parking Assist Control Module																																																									
T	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																									
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																													V	V										
T	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																									
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																													V	V										
T	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
T	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																													V	V										
T	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																									
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
T	2014	Aveo	Powertrain	Chassis Control Module																																																									
T	2014	Aveo	Powertrain	Fuel Injector Control Module																																																									
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2014	Aveo	Chassis	Power Steering Control Module																																																									
T	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2014	Aveo	Body	Body Control Module Hatchback																																																									
T	2014	Aveo	Body	Body Control Module Sedan																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2014	Aveo	Body	Instrument Cluster																																																									
T	2014	Aveo	Body	Radio																																																									
T	2014	Aveo	Body	Telematics Communication Interface Control Module																																																									
T	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
T	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
T	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
T	2014	Aveo	Body	Front Seat Heating Control Module																																																									
T	2014	Aveo	Body	Keyless Entry Control Module																																																									
T	2014	Aveo	Body	Parking Assist Control Module																																																									
T	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																									
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
T	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																												V	V												
T	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																									
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																									
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																									
T	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																									
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																									
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																									
T	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																									
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
T	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
T	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																									
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
T	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
T	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																												V	V												
T	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
T	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																												V	V												
T	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
T	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																									
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																									
T	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																									
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
T	2015	Aveo	Powertrain	Chassis Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2015	Aveo	Powertrain	Fuel Injector Control Module																																																									
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2015	Aveo	Chassis	Power Steering Control Module																																																										
T	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2015	Aveo	Body	Body Control Module Hatchback																																																										
T	2015	Aveo	Body	Body Control Module Sedan																																																										
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Aveo	Body	Instrument Cluster																																																										
T	2015	Aveo	Body	Radio																																																										
T	2015	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2015	Aveo	Body	Front Seat Heating Control Module																																																										
T	2015	Aveo	Body	Keyless Entry Control Module																																																										
T	2015	Aveo	Body	Parking Assist Control Module																																																										
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																													V	V											
T	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																													V	V											
T	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
T	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																													V	V											
T	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
T	2016	Aveo	Powertrain	Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
T	2016	Aveo	Chassis	Power Steering Control Module																																																												
T	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2016	Aveo	Body	Body Control Module Hatchback																																																												
T	2016	Aveo	Body	Body Control Module Sedan																																																												
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	Aveo	Body	Instrument Cluster																																																												
T	2016	Aveo	Body	Radio																																																											
T	2016	Aveo	Body	Telematics Communication Interface Control Module																																																											
T	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
T	2016	Aveo	Body	Front Seat Heating Control Module																																																											
T	2016	Aveo	Body	Parking Assist Control Module																																																											
T	2016	Aveo	Body	Keyless Entry Control Module																																																											
T	2016	Aveo	Body	Frontview Camera Module																																																											
U	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2004	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																											
U	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2004	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																											
U	2004	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
U	2004	ALL	Chassis	Electronic Brake Control Module																																																											
U	2004	ALL	Chassis	Electronic Brake Control Module																																																											
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2004	ALL	Body	Remote Function Actuation																																																											
U	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2005	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																											
U	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2005	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																											
U	2005	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
U	2005	ALL	Chassis	Electronic Brake Control Module																																																											
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2005	ALL	Body	Remote Function Actuation																																																											
U	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2006	ALL	Powertrain	Transmission Control Module																																																											
U	2006	ALL	Chassis	Electronic Brake Control Module																																																											
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2006	ALL	Body	Remote Function Actuation																																																											
U	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2007	ALL	Powertrain	Transmission Control Module																																																											
U	2007	ALL	Chassis	Electronic Brake Control Module																																																											
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
U	2007	ALL	Body	Remote Function Actuation																																																												
U	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																													
U	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																													
U	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																													
U	2008	ALL	Powertrain	Transmission Control Module																																																													
U	2008	ALL	Chassis	Electronic Brake Control Module																																																													
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																													
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																													
U	2008	ALL	Body	Remote Function Actuation																																																													
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																													
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																													
U	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																													
U	2010	Sail	Powertrain	Transmission Control Module																																																													
U	2010	Sail	Chassis	Electronic Brake Control Module																																																													
U	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																													
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																													
U	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																													
U	2011	Sail	Powertrain	Transmission Control Module																																																													
U	2011	Sail	Chassis	Electronic Brake Control Module																																																													
U	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																													
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																													
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																													
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																													
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																													
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																													
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																													
U	2012	Sail	Powertrain	Transmission Control Module																																																													
U	2012	Sail	Chassis	Electronic Brake Control Module																																																													
U	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																													
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																													
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																													
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																													
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																													
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																													
U	2013	Sail	Powertrain	Transmission Control Module																																																													
U	2013	Sail	Chassis	Electronic Brake Control Module																																																													
U	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																													
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																													
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																													
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																													
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																													
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																													
U	2014	Sail	Powertrain	Transmission Control Module																																																													
U	2014	Sail	Chassis	Electronic Brake Control Module																																																													
U	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																													

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																									
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
U	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																										
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
U	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																										
U	2015	Sail	Powertrain	Transmission Control Module																																																										
U	2015	Sail	Chassis	Electronic Brake Control Module																																																										
U	2015	Sail	Chassis	Electronic Brake Control Module																																																										
U	2015	Sail	Chassis	Power Steering Control Module																																																										
U	2015	Sail	Body	Body Control Module																																																										
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
U	2015	Sail	Body	Radio/HVAC Control																																																										
U	2015	Sail	Body	HVAC Control Module																																																										
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
U	2016	Sail	Powertrain	1.2L LMU Transmission Control Module																																																										
U	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																										
U	2016	Sail	Powertrain	1.3L LDV Transmission Control Module																																																										
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
U	2016	Sail	Powertrain	1.4L LCU Transmission Control Module																																																										
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
U	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																										
U	2016	Sail	Chassis	Electronic Brake Control Module																																																										
U	2016	Sail	Chassis	Electronic Brake Control Module																																																										
U	2016	Sail	Chassis	Power Steering Control Module																																																										
U	2016	Sail	Body	Body Control Module																																																										
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
U	2016	Sail	Body	Radio/HVAC Control																																																										
U	2016	Sail	Body	Radio																																																										
U	2016	Sail	Body	HVAC Control Module																																																										
V	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
V	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2004	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																										
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																										
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2004	ALL	Body	ISU																																																										
V	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
V	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										
V	2005	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
V	2005	ALL	Chassis	Electronic Brake Control Module																																																										
V	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2005	ALL	Body	ISU																																																										
V	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
V	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
V	2006	ALL	Powertrain	Transmission Control Module 4 Speed																																																												
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																												
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																												
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2006	ALL	Body	ISU																																																												
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																												
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector Control Module																																																												
V	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
V	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module	V	V	V	V	V	V	V	V																																																				
V	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																												
V	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
V	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																												
V	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																												
V	2007	ALL	Chassis	Electronic Brake Control Module																																																												
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2007	ALL	Body	ISU																																																												
V	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																												
V	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
V	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																												
V	2008	ALL	Chassis	Electronic Brake Control Module																																																												
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2008	ALL	Body	ISU																																																												
V	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																												
V	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
V	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																												
V	2009	ALL	Chassis	Electronic Brake Control Module																																																												
V	2009	ALL	Body	ISU																																																												
V	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module	V	V	V	V	V	V	V	V																																																				
V	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																												
V	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
V	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																												
V	2010	ALL	Chassis	Electronic Brake Control Module																																																												
V	2010	ALL	Body	ISU																																																												
V	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module	V	V	V	V	V	V	V	V																																																				
V	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																												
V	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																												
V	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																												
V	2011	ALL	Chassis	Electronic Brake Control Module																																																												
V	2011	ALL	Body	ISU																																																												
W	2004	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																												
W	2004	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																												
W	2004	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																												
W	2004	ALL	Powertrain	Transmission Control Module																																																												
W	2004	ALL	Body	Body Control Module																																																												
W	2004	ALL	Body	Digital Radio Receiver																																																												
W	2004	ALL	Body	Driver Information Center																																																											
W	2004	ALL	Body	Heating and Air Conditioning																																																												
W	2004	ALL	Body	Instrument Panel Cluster																																																												
W	2004	ALL	Body	Personalization																																																												
W	2004	ALL	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
W	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																											
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																											
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																											
W	2005	ALL	Powertrain	Transmission Control Module																																																											
W	2005	ALL	Body	Body Control Module																																																											
W	2005	ALL	Body	Digital Radio Receiver																																																											
W	2005	ALL	Body	Driver Information Center																																																											
W	2005	ALL	Body	Heating and Air Conditioning																																																											
W	2005	ALL	Body	Instrument Panel Cluster																																																											
W	2005	ALL	Body	Personalization																																																											
W	2005	ALL	Body	Radio																																																											
W	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																											
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																											
W	2006	ALL	Powertrain	Transmission Control Module																																																												
W	2006	ALL	Chassis	Anti-lock Brake System																																																											
W	2006	ALL	Body	Digital Radio Receiver																																																											
W	2006	ALL	Body	Radio																																																											
W	2006	ALL	Body	Instrument Panel Cluster																																																											
W	2006	ALL	Body	Seat																																																											
W	2006	ALL	Body	Theft Deterrent Module																																																											
W	2006	ALL	Body	Body Control Module																																																											
W	2006	ALL	Body	HVAC C67 Single																																																											
W	2006	ALL	Body	HVAC CJ3 Dual																																																											
W	2006	ALL	Body	Remote Control Door Lock Receiver																																																											
W	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
W	2006	ALL	Body	Passenger Presence System																																																											
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																											
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module																																																											
W	2007	ALL	Powertrain	Transmission Control Module																																																											
W	2007	ALL	Chassis	Electronic Brake Control Module																																																											
W	2007	ALL	Body	Body Control Module																																																											
W	2007	ALL	Body	Digital Radio Receiver																																																											
W	2007	ALL	Body	Heated Seat Module																																																											
W	2007	ALL	Body	HVAC C67 Single																																																											
W	2007	ALL	Body	HVAC CJ3 Dual																																																											
W	2007	ALL	Body	Instrument Panel Cluster																																																											
W	2007	ALL	Body	Passenger Presence System																																																											
W	2007	ALL	Body	Radio																																																											
W	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
W	2007	ALL	Body	Theft Deterrent Module																																																											
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module																																																											
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																											
W	2008	ALL	Powertrain	Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
W	2008	ALL	Chassis	Electronic Brake Control Module																																																										
W	2008	ALL	Body	Body Control Module																																																										
W	2008	ALL	Body	Digital Radio Receiver																																																										
W	2008	ALL	Body	Heated Seat Module																																																										
W	2008	ALL	Body	HVAC C67 Single																																																										
W	2008	ALL	Body	HVAC CJ3 Dual																																																										
W	2008	ALL	Body	Instrument Panel Cluster																																																										
W	2008	ALL	Body	Passenger Presence System																																																										
W	2008	ALL	Body	Radio																																																										
W	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2008	ALL	Body	Theft Deterrent Module																																																										
W	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
W	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
W	2009	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																										
W	2009	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																										
W	2009	ALL	Powertrain	Transmission Control Module																																																										
W	2009	ALL	Chassis	Electronic Brake Control Module																																																										
W	2009	ALL	Body	Body Control Module																																																										
W	2009	ALL	Body	Digital Radio Receiver																																																										
W	2009	ALL	Body	Heated Seat Module																																																										
W	2009	ALL	Body	HVAC C67 Single																																																										
W	2009	ALL	Body	HVAC CJ3 Dual																																																										
W	2009	ALL	Body	Instrument Panel Cluster																																																										
W	2009	ALL	Body	Passenger Presence System																																																										
W	2009	ALL	Body	Radio																																																										
W	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2009	ALL	Body	Theft Deterrent Module																																																										
W	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
W	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
W	2010	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																										
W	2010	ALL	Powertrain	Transmission Control Module																																																										
W	2010	ALL	Chassis	Electronic Brake Control Module																																																										
W	2010	ALL	Body	Body Control Module																																																										
W	2010	ALL	Body	Digital Radio Receiver																																																										
W	2010	ALL	Body	Heated Seat Module																																																										
W	2010	ALL	Body	HVAC C67 Single																																																										
W	2010	ALL	Body	HVAC CJ3 Dual																																																										
W	2010	ALL	Body	Instrument Panel Cluster																																																										
W	2010	ALL	Body	Passenger Presence System																																																										
W	2010	ALL	Body	Radio																																																										
W	2010	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2010	ALL	Body	Theft Deterrent Module																																																										
W	2011	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																										
W	2011	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																										
W	2011	ALL	Powertrain	Transmission Control Module																																																										
W	2011	ALL	Chassis	Electronic Brake Control Module																																																										
W	2011	ALL	Body	Body Control Module																																																										
W	2011	ALL	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
W	2011	ALL	Body	Heated Seat Module																																																										
W	2011	ALL	Body	HVAC C67 Single																																																										
W	2011	ALL	Body	HVAC CJ3 Dual																																																										
W	2011	ALL	Body	Instrument Panel Cluster																																																										
W	2011	ALL	Body	Passenger Presence System																																																										
W	2011	ALL	Body	Radio																																																										
W	2011	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2011	ALL	Body	Theft Deterrent Module																																																										
W	2012	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																										V																																	
W	2012	ALL	Powertrain	Transmission Control Module																																																										
W	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
W	2012	ALL	Chassis	Electronic Brake Control Module																																																										
W	2012	ALL	Body	Body Control Module																																																										
W	2012	ALL	Body	Digital Radio Receiver																																																										
W	2012	ALL	Body	Heated Seat Module																																																										
W	2012	ALL	Body	HVAC C67 Single																																																										
W	2012	ALL	Body	HVAC CJ3 Dual																																																										
W	2012	ALL	Body	Instrument Panel Cluster																																																										
W	2012	ALL	Body	Passenger Presence System																																																										
W	2012	ALL	Body	Radio																																																										
W	2012	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2012	ALL	Body	Theft Deterrent Module																																																										
W	2013	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
W	2013	ALL	Powertrain	Transmission Control Module																																																										
W	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
W	2013	ALL	Chassis	Electronic Brake Control Module																																																										
W	2013	ALL	Body	Body Control Module																																																										
W	2013	ALL	Body	Digital Radio Receiver																																																										
W	2013	ALL	Body	Heated Seat Module																																																										
W	2013	ALL	Body	HVAC C67 Single																																																										
W	2013	ALL	Body	HVAC CJ3 Dual																																																										
W	2013	ALL	Body	Instrument Panel Cluster																																																										
W	2013	ALL	Body	Passenger Presence System																																																										
W	2013	ALL	Body	Radio																																																										
W	2013	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2013	ALL	Body	Theft Deterrent Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
W	2014	Impala	Chassis	Electronic Brake Control Module																																																										
W	2014	Impala	Body	Body Control Module																																																										
W	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2014	Impala	Body	Passenger Presence Module																																																										
W	2014	Impala	Body	Instrument Cluster																																																										
W	2014	Impala	Body	Radio																																																										
W	2014	Impala	Body	Digital Radio Receiver Control Module																																																										
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																										
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
W	2014	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
W	2014	Impala	Body	HVAC Manual Control Single Zone (C67)																																																											
W	2014	Impala	Body	Front Seat Heating Control Module																																																											
W	2014	Impala	Body	Remote Control Door Lock Receiver																																																											
W	2014	Impala	Body	Theft Deterrent Module																																																											
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																											
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																											
W	2014	Lumina	Powertrain	(2) 6.0L L77 Transmission Control Module																																																											
W	2014	Lumina	Powertrain	Fuel Injector Control Module																																																											
W	2014	Lumina	Powertrain	Chassis Control Module																																																											
W	2014	Lumina	Chassis	Electronic Brake Control Module																																																											
W	2014	Lumina	Chassis	Parking Brake Control Module																																																											
W	2014	Lumina	Chassis	Power Steering Control Module																																																											
W	2014	Lumina	Chassis	Steering Wheel Angle Sensor Module																																																											
W	2014	Lumina	Chassis	Suspension Control Module																																																											
W	2014	Lumina	Body	Body Control Module Coupe																																																											
W	2014	Lumina	Body	Body Control Module Sedan																																																											
W	2014	Lumina	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
W	2014	Lumina	Body	Instrument Cluster																																																											
W	2014	Lumina	Body	Head-Up Display Module																																																											
W	2014	Lumina	Body	Radio Control																																																											
W	2014	Lumina	Body	HVAC Control																																																											
W	2014	Lumina	Body	Headlamp Control Module																																																											
W	2014	Lumina	Body	Trailer Interface Control Module																																																											
W	2014	Lumina	Body	Radio																																																											
W	2014	Lumina	Body	HVAC Control Module																																																											
W	2014	Lumina	Body	Keyless Entry Control Module																																																											
W	2014	Lumina	Body	Right Side Object Detection Control Module																																																											
W	2014	Lumina	Body	Left Side Object Detection Control Module																																																											
W	2014	Lumina	Body	Parking Assist Control Module																																																											
W	2014	Lumina	Body	Frontview Camera Module																																																											
W	2014	Lumina	Body	Steering Column Lock Control Module																																																											
W	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
W	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
W	2015	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																											
W	2015	Impala	Chassis	Electronic Brake Control Module																																																											
W	2015	Impala	Body	Body Control Module																																																											
W	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
W	2015	Impala	Body	Passenger Presence Module																																																											
W	2015	Impala	Body	Instrument Cluster																																																											
W	2015	Impala	Body	Radio																																																											
W	2015	Impala	Body	Digital Radio Receiver Control Module																																																											
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 9																																																											
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 10																																																											
W	2015	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
W	2015	Impala	Body	HVAC Manual Control Single Zone (C67)																																																											
W	2015	Impala	Body	Front Seat Heating Control Module																																																											
W	2015	Impala	Body	Remote Control Door Lock Receiver																																																											
W	2015	Impala	Body	Theft Deterrent Module																																																											
W	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
W	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
W	2016	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																												
W	2016	Impala	Chassis	Electronic Brake Control Module																																																												
W	2016	Impala	Body	Body Control Module																																																											
W	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
W	2016	Impala	Body	Passenger Presence Module																																																												
W	2016	Impala	Body	Instrument Cluster																																																												
W	2016	Impala	Body	Radio																																																												
W	2016	Impala	Body	Digital Radio Receiver Control Module																																																												
W	2016	Impala	Body	Telematics Communication Interface Control Module																																																												
W	2016	Impala	Body	HVAC Manual Control Dual Zone (CJ2)																																																												
W	2016	Impala	Body	HVAC Manual Control Single Zone (C67)																																																												
W	2016	Impala	Body	Front Seat Heating Control Module																																																												
W	2016	Impala	Body	Remote Control Door Lock Receiver																																																												
W	2016	Impala	Body	Theft Deterrent Module																																																												
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Auto																																																												
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Manual																																																												
Y	2004	ALL	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																												
Y	2004	ALL	Powertrain	Transmission Control Module																																																												
Y	2004	ALL	Chassis	RTD																																																												
Y	2004	ALL	Body	Body Control Module																																																												
Y	2004	ALL	Body	Heating and Air Conditioning																																																												
Y	2004	ALL	Body	Instrument Panel Cluster																																																												
Y	2004	ALL	Body	Left Door Control Module																																																												
Y	2004	ALL	Body	Radio																																																												
Y	2004	ALL	Body	Remote Function Actuation																																																												
Y	2004	ALL	Body	Right Door Control Module																																																												
Y	2004	ALL	Body	Seat Control Module																																																												
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2005	ALL	Powertrain	Engine Control Module																																																												
Y	2005	ALL	Powertrain	Transmission Control Module																																																												
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2005	ALL	Chassis	Electronic Suspension Control																																																												
Y	2005	ALL	Chassis	Steering Wheel and Column																																																												
Y	2005	ALL	Body	Amplifier																																																												
Y	2005	ALL	Body	Body Control Module																																																												
Y	2005	ALL	Body	Digital Radio Receiver																																																												
Y	2005	ALL	Body	Driver Door Module																																																												
Y	2005	ALL	Body	Driver Door Switch																																																												
Y	2005	ALL	Body	Driver Position Module																																																												
Y	2005	ALL	Body	Folding Top Module																																																												
Y	2005	ALL	Body	Head Up Display																																																												
Y	2005	ALL	Body	HVAC Control Module																																																												
Y	2005	ALL	Body	Instrument Panel Cluster																																																												
Y	2005	ALL	Body	Navigation Radio																																																												
Y	2005	ALL	Body	Passenger Door Module																																																												
Y	2005	ALL	Body	Radio																																																												
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2006	ALL	Powertrain	Engine Control Module																																																												
Y	2006	ALL	Powertrain	Exhaust Flow Control Module																																																												
Y	2006	ALL	Powertrain	Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Y	2006	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2006	ALL	Chassis	Electronic Suspension Control																																																											
Y	2006	ALL	Chassis	Steering Wheel and Column																																																											
Y	2006	ALL	Body	Body Control Module																																																										
Y	2006	ALL	Body	CD Changer																																																										
Y	2006	ALL	Body	Digital Radio Receiver																																																										
Y	2006	ALL	Body	Driver Door Module																																																										
Y	2006	ALL	Body	Driver Door Switch																																																										
Y	2006	ALL	Body	Driver Position Module																																																										
Y	2006	ALL	Body	Folding Top Module																																																										
Y	2006	ALL	Body	Head Up Display																																																										
Y	2006	ALL	Body	HVAC Control Module																																																										
Y	2006	ALL	Body	Instrument Panel Cluster																																																										
Y	2006	ALL	Body	Navigation Radio																																																										
Y	2006	ALL	Body	Passenger Door Module																																																										
Y	2006	ALL	Body	Radio																																																										
Y	2006	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2007	ALL	Powertrain	Engine Control Module																																																										
Y	2007	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	ALL	Powertrain	Transmission Control Module																																																										
Y	2007	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2007	ALL	Chassis	Electronic Suspension Control																																																										
Y	2007	ALL	Body	Body Control Module																																																										
Y	2007	ALL	Body	CD Changer																																																										
Y	2007	ALL	Body	Digital Radio Receiver																																																										
Y	2007	ALL	Body	Driver Door Module																																																										
Y	2007	ALL	Body	Driver Door Switch																																																										
Y	2007	ALL	Body	Driver Position Module																																																										
Y	2007	ALL	Body	Folding Top Module																																																										
Y	2007	ALL	Body	Head Up Display																																																										
Y	2007	ALL	Body	HVAC Control Module																																																										
Y	2007	ALL	Body	Instrument Panel Cluster																																																										
Y	2007	ALL	Body	Navigation Radio																																																										
Y	2007	ALL	Body	Passenger Door Module																																																										
Y	2007	ALL	Body	Radio																																																										
Y	2007	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2007	ALL	Body	Steering Column Lock Module																																																										
Y	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Powertrain	Engine Control Module																																																										
Y	2008	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2008	ALL	Powertrain	Transmission Control Module																																																										
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2008	ALL	Chassis	Electronic Suspension Control																																																										
Y	2008	ALL	Body	Body Control Module																																																										
Y	2008	ALL	Body	CD Changer																																																										
Y	2008	ALL	Body	Digital Radio Receiver																																																										
Y	2008	ALL	Body	Driver Door Module																																																										
Y	2008	ALL	Body	Driver Door Switch																																																										
Y	2008	ALL	Body	Driver Position Module																																																										
Y	2008	ALL	Body	Folding Top Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Y	2008	ALL	Body	Head Up Display																																																									
Y	2008	ALL	Body	HVAC Control Module																																																									
Y	2008	ALL	Body	Instrument Panel Cluster																																																									
Y	2008	ALL	Body	Navigation Radio																																																									
Y	2008	ALL	Body	Passenger Door Module																																																									
Y	2008	ALL	Body	Radio																																																									
Y	2008	ALL	Body	Personal Audio Link Module																																																									
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																									
Y	2008	ALL	Body	Steering Column Lock Module																																																									
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																									
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																									
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																									
Y	2009	ALL	Chassis	Electronic Brake Control Module																																																									
Y	2009	ALL	Chassis	Electronic Suspension Control																																																									
Y	2009	ALL	Body	Body Control Module																																																									
Y	2009	ALL	Body	CD Changer																																																									
Y	2009	ALL	Body	Digital Radio Receiver																																																									
Y	2009	ALL	Body	Driver Door Module																																																									
Y	2009	ALL	Body	Driver Door Switch																																																									
Y	2009	ALL	Body	Driver Position Module																																																									
Y	2009	ALL	Body	Folding Top Module																																																									
Y	2009	ALL	Body	Head Up Display																																																									
Y	2009	ALL	Body	HVAC Control Module																																																									
Y	2009	ALL	Body	Instrument Panel Cluster																																																									
Y	2009	ALL	Body	Navigation Radio																																																									
Y	2009	ALL	Body	Passenger Door Module																																																									
Y	2009	ALL	Body	Radio																																																									
Y	2009	ALL	Body	Personal Audio Link Module																																																									
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																																									
Y	2009	ALL	Body	Steering Column Lock Module																																																									
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																									
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																									
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																									
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																									
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																									
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																									
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																									
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																									
Y	2010	ALL	Chassis	Electronic Brake Control Module																																																									
Y	2010	ALL	Chassis	Electronic Suspension Control																																																									
Y	2010	ALL	Body	Body Control Module																																																									
Y	2010	ALL	Body	CD Changer																																																									
Y	2010	ALL	Body	Digital Radio Receiver																																																									
Y	2010	ALL	Body	Driver Door Module																																																									
Y	2010	ALL	Body	Driver Door Switch																																																									
Y	2010	ALL	Body	Driver Position Module																																																									
Y	2010	ALL	Body	Folding Top Module																																																									
Y	2010	ALL	Body	Head Up Display																																																									
Y	2010	ALL	Body	HVAC Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Y	2010	ALL	Body	Instrument Panel Cluster																																																												
Y	2010	ALL	Body	Navigation Radio																																																												
Y	2010	ALL	Body	Passenger Door Module																																																												
Y	2010	ALL	Body	Radio																																																												
Y	2010	ALL	Body	Personal Audio Link Module																																																												
Y	2010	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2010	ALL	Body	Steering Column Lock Module																																																												
Y	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																												
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																												
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																												
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																												
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																												
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																												
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																												
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																												
Y	2011	ALL	Chassis	Electronic Brake Control Module																																																													
Y	2011	ALL	Chassis	Electronic Suspension Control																																																													
Y	2011	ALL	Body	Body Control Module																																																												
Y	2011	ALL	Body	CD Changer																																																												
Y	2011	ALL	Body	Digital Radio Receiver																																																												
Y	2011	ALL	Body	Driver Door Module																																																												
Y	2011	ALL	Body	Driver Door Switch																																																												
Y	2011	ALL	Body	Driver Position Module																																																												
Y	2011	ALL	Body	Folding Top Module																																																												
Y	2011	ALL	Body	Head Up Display																																																												
Y	2011	ALL	Body	HVAC Control Module																																																												
Y	2011	ALL	Body	Instrument Panel Cluster																																																												
Y	2011	ALL	Body	Navigation Radio																																																												
Y	2011	ALL	Body	Passenger Door Module																																																												
Y	2011	ALL	Body	Radio																																																												
Y	2011	ALL	Body	Personal Audio Link Module																																																												
Y	2011	ALL	Body	Remote Control Door Lock Receiver																																																												
Y	2011	ALL	Body	Steering Column Lock Module																																																												
Y	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																												
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																												
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																												
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																												
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																												
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																												
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																												
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																												
Y	2012	ALL	Chassis	Electronic Brake Control Module																																																												
Y	2012	ALL	Chassis	Electronic Suspension Control																																																												
Y	2012	ALL	Body	Body Control Module																																																												
Y	2012	ALL	Body	CD Changer																																																												
Y	2012	ALL	Body	Digital Radio Receiver																																																												
Y	2012	ALL	Body	Driver Door Module																																																												
Y	2012	ALL	Body	Driver Door Switch																																																												
Y	2012	ALL	Body	Driver Position Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Y	2012	ALL	Body	Folding Top Module																																																										
Y	2012	ALL	Body	Head Up Display																																																										
Y	2012	ALL	Body	HVAC Control Module																																																										
Y	2012	ALL	Body	Instrument Panel Cluster																																																										
Y	2012	ALL	Body	Navigation Radio																																																										
Y	2012	ALL	Body	Passenger Door Module																																																										
Y	2012	ALL	Body	Radio																																																										
Y	2012	ALL	Body	Personal Audio Link Module																																																										
Y	2012	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2012	ALL	Body	Steering Column Lock Module																																																										
Y	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																										
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																										
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																										
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																										
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2013	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2013	ALL	Chassis	Electronic Suspension Control																																																										
Y	2013	ALL	Body	Body Control Module																																																										
Y	2013	ALL	Body	CD Changer																																																										
Y	2013	ALL	Body	Digital Radio Receiver																																																										
Y	2013	ALL	Body	Driver Door Module																																																										
Y	2013	ALL	Body	Driver Door Switch																																																										
Y	2013	ALL	Body	Driver Position Module																																																										
Y	2013	ALL	Body	Folding Top Module																																																										
Y	2013	ALL	Body	Head Up Display																																																										
Y	2013	ALL	Body	HVAC Control Module																																																										
Y	2013	ALL	Body	Instrument Panel Cluster																																																										
Y	2013	ALL	Body	Navigation Radio																																																										
Y	2013	ALL	Body	Passenger Door Module																																																										
Y	2013	ALL	Body	Radio																																																										
Y	2013	ALL	Body	Personal Audio Link Module																																																										
Y	2013	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2013	ALL	Body	Steering Column Lock Module																																																										
Y	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																										
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																										
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																										
Y	2014	Corvette	Powertrain	Chassis Control Module																																																										
Y	2014	Corvette	Chassis	Electronic Brake Control Module																																																										
Y	2014	Corvette	Chassis	Parking Brake Control Module																																																										
Y	2014	Corvette	Chassis	Power Steering Control Module																																																										
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																										
Y	2014	Corvette	Chassis	Suspension Control Module																																																										
Y	2014	Corvette	Body	Body Control Module Convertible																																																										
Y	2014	Corvette	Body	Body Control Module Coupe																																																										
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Y	2014	Corvette	Body	Passenger Presence Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Y	2014	Corvette	Body	Instrument Cluster																																																										
Y	2014	Corvette	Body	Radio/HVAC Control																																																											
Y	2014	Corvette	Body	Inside Rearview Mirror																																																											
Y	2014	Corvette	Body	Radio																																																											
Y	2014	Corvette	Body	Amplifier																																																											
Y	2014	Corvette	Body	Human Machine Interface Control Module																																																											
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																											
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																											
Y	2014	Corvette	Body	HVAC Control Module																																																											
Y	2014	Corvette	Body	Seat Memory Control Module - Passenger																																																											
Y	2014	Corvette	Body	Seat Memory Control Module - Driver																																																											
Y	2014	Corvette	Body	Folding Top Control Module																																																											
Y	2014	Corvette	Body	Keyless Entry Control Module																																																											
Y	2014	Corvette	Body	Steering Column Lock Control Module																																																											
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																											
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																											
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																											
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Automatic Transmission																																																											
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Manual Transmission																																																											
Y	2015	Corvette	Powertrain	6.2L LT4 Transmission Control Module																																																											
Y	2015	Corvette	Powertrain	Chassis Control Module																																																											
Y	2015	Corvette	Chassis	Electronic Brake Control Module																																																											
Y	2015	Corvette	Chassis	Parking Brake Control Module																																																											
Y	2015	Corvette	Chassis	Power Steering Control Module																																																											
Y	2015	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																											
Y	2015	Corvette	Chassis	Suspension Control Module																																																											
Y	2015	Corvette	Body	Body Control Module Convertible																																																											
Y	2015	Corvette	Body	Body Control Module Coupe																																																											
Y	2015	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
Y	2015	Corvette	Body	Passenger Presence Module																																																											
Y	2015	Corvette	Body	Instrument Cluster																																																											
Y	2015	Corvette	Body	Radio/HVAC Control																																																											
Y	2015	Corvette	Body	Vehicle Performance Data Recorder																																																											
Y	2015	Corvette	Body	Inside Rearview Mirror																																																											
Y	2015	Corvette	Body	Radio																																																											
Y	2015	Corvette	Body	Amplifier																																																											
Y	2015	Corvette	Body	Human Machine Interface Control Module																																																											
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																											
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																											
Y	2015	Corvette	Body	HVAC Control Module																																																											
Y	2015	Corvette	Body	Seat Memory Control Module - Passenger																																																											
Y	2015	Corvette	Body	Seat Memory Control Module - Driver																																																											
Y	2015	Corvette	Body	Folding Top Control Module																																																											
Y	2015	Corvette	Body	Keyless Entry Control Module																																																											
Y	2015	Corvette	Body	Steering Column Lock Control Module																																																											
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																											
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																											
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Automatic Transmission																																																											
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Manual Transmission																																																											
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Y	2016	Corvette	Powertrain	Rear Differential Clutch Control Module																																																										
Y	2016	Corvette	Chassis	Electronic Brake Control Module																																																											
Y	2016	Corvette	Chassis	Parking Brake Control Module																																																											
Y	2016	Corvette	Chassis	Power Steering Control Module																																																											
Y	2016	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																											
Y	2016	Corvette	Chassis	Suspension Control Module																																																											
Y	2016	Corvette	Body	Body Control Module																																																											
Y	2016	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
Y	2016	Corvette	Body	Passenger Presence Module																																																											
Y	2016	Corvette	Body	Instrument Cluster																																																											
Y	2016	Corvette	Body	Radio/HVAC Control																																																											
Y	2016	Corvette	Body	Vehicle Performance Data Recorder																																																											
Y	2016	Corvette	Body	Video Processing Control Module																																																											
Y	2016	Corvette	Body	Inside Rearview Mirror																																																											
Y	2016	Corvette	Body	Radio																																																											
Y	2016	Corvette	Body	Amplifier																																																											
Y	2016	Corvette	Body	Human Machine Interface Control Module																																																											
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																											
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																											
Y	2016	Corvette	Body	HVAC Control Module																																																											
Y	2016	Corvette	Body	Liftgate Control Module																																																											
Y	2016	Corvette	Body	Seat Memory Control Module - Passenger																																																											
Y	2016	Corvette	Body	Seat Memory Control Module - Driver																																																											
Y	2016	Corvette	Body	Folding Top Control Module																																																											
Y	2016	Corvette	Body	Keyless Entry Control Module																																																											
Y	2016	Corvette	Body	Steering Column Lock Control Module																																																											
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																											
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																											
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																											
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																											
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																											
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																											
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																											
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																											
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																											
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																											
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																											
Y	2016	Cruze	Chassis	Electronic Brake Control Module																																																											
Y	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																											
Y	2016	Cruze	Chassis	Power Steering Control Module																																																											
Y	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
Y	2016	Cruze	Body	Body Control Module																																																											
Y	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
Y	2016	Cruze	Body	Passenger Presence Module																																																											
Y	2016	Cruze	Body	Instrument Cluster																																																											
Y	2016	Cruze	Body	Radio Controls																																																											
Y	2016	Cruze	Body	HVAC Controls																																																											
Y	2016	Cruze	Body	Trailer Interface Control Module																																																											
Y	2016	Cruze	Body	Radio Base (IO3 IO7)																																																											
Y	2016	Cruze	Body	Radio (IOA)																																																											
Y	2016	Cruze	Body	Radio (IOB)																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Y	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																									
Y	2016	Cruze	Body	Amplifier																																																									
Y	2016	Cruze	Body	Multimedia Player Interface Module																																																										
Y	2016	Cruze	Body	Human Machine Interface Control Module																																																										
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
Y	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																										
Y	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																										
Y	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																										
Y	2016	Cruze	Body	Keyless Entry Control Module																																																										
Y	2016	Cruze	Body	Right Side Object Detection Control Module																																																										
Y	2016	Cruze	Body	Left Side Object Detection Control Module																																																										
Y	2016	Cruze	Body	Parking Assist Control Module																																																										
Y	2016	Cruze	Body	Frontview Camera Module																																																										
Y	2016	Cruze	Body	Steering Column Lock Control Module																																																										
Y	2016	Cruze	Body	Long Range Radar Sensor Module																																																										
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																										
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Transmission Control Module																																																										
Z	2004	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2004	ALL	Chassis	Power Steering Control Module																																																										
Z	2004	ALL	Body	Body Control Module																																																										
Z	2004	ALL	Body	Digital Radio Receiver																																																										
Z	2004	ALL	Body	HVAC Control Module																																																										
Z	2004	ALL	Body	Instrument Panel Cluster																																																										
Z	2004	ALL	Body	Radio																																																										
Z	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2004	ALL	Body	Theft Deterrent Module																																																										
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2005	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																										
Z	2005	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2005	ALL	Chassis	Power Steering Control Module																																																										
Z	2005	ALL	Body	Body Control Module																																																										
Z	2005	ALL	Body	Digital Radio Receiver																																																										
Z	2005	ALL	Body	HVAC Control Module																																																										
Z	2005	ALL	Body	Instrument Panel Cluster																																																										
Z	2005	ALL	Body	Radio																																																										
Z	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2005	ALL	Body	Theft Deterrent Module																																																										
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2006	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																																										
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
Z	2006	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2006	ALL	Chassis	Power Steering Control Module																																																										
Z	2006	ALL	Body	Body Control Module																																																										
Z	2006	ALL	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Z	2006	ALL	Body	HVAC Control Module																																																										
Z	2006	ALL	Body	Instrument Panel Cluster																																																											
Z	2006	ALL	Body	Radio																																																										
Z	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2006	ALL	Body	Theft Deterrent Module																																																										
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																										
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
Z	2007	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2007	ALL	Chassis	Power Steering Control Module																																																										
Z	2007	ALL	Body	Body Control Module																																																										
Z	2007	ALL	Body	Digital Radio Receiver																																																										
Z	2007	ALL	Body	Disc Player and Video Display																																																										
Z	2007	ALL	Body	HVAC Control Module																																																										
Z	2007	ALL	Body	Instrument Panel Cluster																																																										
Z	2007	ALL	Body	Radio																																																										
Z	2007	ALL	Body	Remote Control Door Lock Receiver																																																										
Z	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2007	ALL	Body	Theft Deterrent Module																																																										
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																										
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																										
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																										
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																										
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
Z	2008	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2008	ALL	Chassis	Power Steering Control Module																																																										
Z	2008	ALL	Body	Body Control Module Classic																																																										
Z	2008	ALL	Body	Body Control Module Malibu																																																										
Z	2008	ALL	Body	Digital Radio Receiver																																																										
Z	2008	ALL	Body	Disc Player and Video Display																																																										
Z	2008	ALL	Body	HVAC Control Module Classic																																																										
Z	2008	ALL	Body	HVAC Control Module Malibu																																																										
Z	2008	ALL	Body	Instrument Panel Cluster Classic																																																										
Z	2008	ALL	Body	Instrument Panel Cluster Malibu																																																										
Z	2008	ALL	Body	Radio																																																										
Z	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
Z	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2008	ALL	Body	Theft Deterrent Module																																																										
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																										
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																										
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																										
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump																																																										
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump																																																										
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Without Tap Shift																																																										
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																											
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
Z	2009	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2009	ALL	Chassis	Power Steering Control Module																																																											
Z	2009	ALL	Body	Body Control Module																																																											
Z	2009	ALL	Body	Digital Radio Receiver																																																											
Z	2009	ALL	Body	Disc Player and Video Display																																																											
Z	2009	ALL	Body	HVAC Control Module																																																											
Z	2009	ALL	Body	Instrument Panel Cluster																																																											
Z	2009	ALL	Body	Personal Audio Link Module																																																											
Z	2009	ALL	Body	Radio																																																											
Z	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2009	ALL	Body	Theft Deterrent Module																																																											
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																											
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																											
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																											
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Engine Control Module																																																											
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 6 Speed																																																											
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 4 Speed																																																											
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																											
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																											
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
Z	2010	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2010	ALL	Chassis	Power Steering Control Module																																																											
Z	2010	ALL	Body	Body Control Module																																																											
Z	2010	ALL	Body	Digital Radio Receiver																																																											
Z	2010	ALL	Body	HVAC Control Module																																																											
Z	2010	ALL	Body	Instrument Panel Cluster																																																											
Z	2010	ALL	Body	Personal Audio Link Module																																																											
Z	2010	ALL	Body	Radio																																																											
Z	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2010	ALL	Body	Theft Deterrent Module																																																											
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																											
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																											
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																											
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																											
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
Z	2011	ALL	Chassis	Electronic Brake Control Module																																																											
Z	2011	ALL	Chassis	Power Steering Control Module																																																											
Z	2011	ALL	Body	Body Control Module																																																											
Z	2011	ALL	Body	Digital Radio Receiver																																																											
Z	2011	ALL	Body	HVAC Control Module																																																											
Z	2011	ALL	Body	Instrument Panel Cluster																																																											
Z	2011	ALL	Body	Personal Audio Link Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Z	2011	ALL	Body	Radio																																																										
Z	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2011	ALL	Body	Theft Deterrent Module																																																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Engine Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Transmission Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Chassis	Electronic Brake Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Chassis	Power Steering Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Body	Body Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Body	Digital Radio Receiver																																																										
Z	2012	Malibu (Seventh Gen)	Body	HVAC Control Module																																																										
Z	2012	Malibu (Seventh Gen)	Body	Instrument Panel Cluster																																																										
Z	2012	Malibu (Seventh Gen)	Body	Personal Audio Link Module																																																										
Z	2012	Malibu (Seventh Gen)	Body	Radio																																																										
Z	2012	Malibu (Seventh Gen)	Body	Supplemental Inflatable Restraint																																																										
Z	2012	Malibu (Seventh Gen)	Body	Theft Deterrent Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Transmission Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Transmission Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Fuel Pump Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Transmission Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Fuel Pump Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Powertrain	Rear Differential Clutch Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Chassis	Electronic Brake Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Chassis	Parking Brake Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
Z	2012	Malibu (Eighth Gen)	Chassis	Power Steering Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
Z	2012	Malibu (Eighth Gen)	Chassis	Suspension Control Module																																																										
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																										
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																										
Z	2012	Malibu (Eighth Gen)	Body	Passenger Presence Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Z	2012	Malibu (Eighth Gen)	Body	Instrument Cluster																																																										
Z	2012	Malibu (Eighth Gen)	Body	Head-Up Display Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Headlamp Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Radio																																																											
Z	2012	Malibu (Eighth Gen)	Body	Digital Radio Receiver Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Multimedia Player Interface Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Mobile Telephone Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Dual (CJ2)																																																											
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Single (C68)																																																											
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Manual Single (C67)																																																											
Z	2012	Malibu (Eighth Gen)	Body	Rear Seat Heating Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Keyless Entry Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Right Side Object Detection Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Left Side Object Detection Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Parking Assist Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Vehicle Direction Camera Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Steering Column Lock Control Module																																																											
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Engine Control Module																																																											
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Transmission Control Module																																																											
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Engine Control Module																																																											
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 1																																																											
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 2																																																											
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module																																																											
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 6 Speed (MNM)																																																											
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 8 Speed (MRC)																																																											
Z	2016	Malibu	Chassis	Electronic Brake Control Module																																																											
Z	2016	Malibu	Chassis	Brake Booster Control Module																																																											
Z	2016	Malibu	Chassis	Power Steering Control Module																																																											
Z	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
Z	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
Z	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
Z	2016	Malibu	Body	Passenger Presence Module																																																											
Z	2016	Malibu	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
Z	2016	Malibu	Body	Instrument Cluster Enhanced Monochrome Driver Info Center (UDC)																																																											
Z	2016	Malibu	Body	Radio Controls																																																											
Z	2016	Malibu	Body	HVAC Controls																																																											
Z	2016	Malibu	Body	Active Safety Control Module																																																											
Z	2016	Malibu	Body	Headlamp Control Module																																																											
Z	2016	Malibu	Body	Radio Base																																																											
Z	2016	Malibu	Body	Radio (IOA)																																																											
Z	2016	Malibu	Body	Radio Uplevel (IO4 IO5 IO6)																																																											
Z	2016	Malibu	Body	Amplifier																																																											
Z	2016	Malibu	Body	Human Machine Interface Control Module																																																											
Z	2016	Malibu	Body	Navigation Control Module																																																											
Z	2016	Malibu	Body	Mobile Telephone Control Module																																																											
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																											
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																											
Z	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
Z	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											
Z	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																											
Z	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
Z	2016	Malibu	Body	Electric A/C Compressor Control Module																																																										
Z	2016	Malibu	Body	Seat Memory Control Module - Driver																																																											
Z	2016	Malibu	Body	Keyless Entry Control Module																																																											
Z	2016	Malibu	Body	Right Side Object Detection Control Module																																																											
Z	2016	Malibu	Body	Left Side Object Detection Control Module																																																											
Z	2016	Malibu	Body	Parking Assist Control Module																																																											
Z	2016	Malibu	Body	Frontview Camera Module																																																											
Z	2016	Malibu	Body	Frontview Camera Module																																																											
Z	2016	Malibu	Body	Steering Column Lock Control Module																																																											
Z	2016	Malibu	Body	Long Range Radar Sensor Module																																																											
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
1	2013	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2013	Malibu	Chassis	Parking Brake Control Module																																																										
1	2013	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2013	Malibu	Chassis	Power Steering Control Module																																																										
1	2013	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2013	Malibu	Chassis	Suspension Control Module																																																										
1	2013	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2013	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																										
1	2013	Malibu	Body	Passenger Presence Module																																																											
1	2013	Malibu	Body	Instrument Cluster																																																											
1	2013	Malibu	Body	Headlamp Control Module																																																											
1	2013	Malibu	Body	Radio																																																											
1	2013	Malibu	Body	Digital Radio Receiver Control Module																																																											
1	2013	Malibu	Body	Multimedia Player Interface Module																																																											
1	2013	Malibu	Body	Mobile Telephone Control Module																																																											
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2013	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
1	2013	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											
1	2013	Malibu	Body	HVAC Control Module Manual Single (C67)																																																											
1	2013	Malibu	Body	Rear Seat Heating Control Module																																																											
1	2013	Malibu	Body	Keyless Entry Control Module																																																											
1	2013	Malibu	Body	Parking Assist Control Module																																																											
1	2013	Malibu	Body	Vehicle Direction Camera Control Module																																																											
1	2013	Malibu	Body	Steering Column Lock Control Module																																																											
1	2013	Malibu	Body	Battery Energy Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																											
1	2014	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																											
1	2014	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																											
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																											
1	2014	Impala	Chassis	Electronic Brake Control Module																																																											
1	2014	Impala	Chassis	Distance Sensing Cruise Control Module																																																											
1	2014	Impala	Chassis	Parking Brake Control Module																																																											
1	2014	Impala	Chassis	Power Steering Control Module																																																											
1	2014	Impala	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2014	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	Impala	Body	Passenger Presence Module																																																											
1	2014	Impala	Body	Instrument Cluster																																																											
1	2014	Impala	Body	Radio Control																																																											
1	2014	Impala	Body	HVAC Control																																																											
1	2014	Impala	Body	Radio																																																											
1	2014	Impala	Body	Amplifier																																																											
1	2014	Impala	Body	Human Machine Interface Control Module																																																											
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Impala	Body	HVAC Control Module																																																											
1	2014	Impala	Body	Keyless Entry Control Module																																																											
1	2014	Impala	Body	Right Side Object Detection Control Module																																																											
1	2014	Impala	Body	Left Side Object Detection Control Module																																																											
1	2014	Impala	Body	Parking Assist Control Module																																																											
1	2014	Impala	Body	Frontview Camera Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2014	Impala	Body	Steering Column Lock Control Module																																																										
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
1	2014	Malibu	Chassis	Electronic Brake Control Module																																																											
1	2014	Malibu	Chassis	Parking Brake Control Module																																																											
1	2014	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2014	Malibu	Chassis	Power Steering Control Module																																																											
1	2014	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Malibu	Chassis	Suspension Control Module																																																											
1	2014	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																									V																	
1	2014	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																									V																	
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																											
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																											
1	2014	Malibu	Body	Passenger Presence Module																																																											
1	2014	Malibu	Body	Instrument Cluster																																																											
1	2014	Malibu	Body	Headlamp Control Module																																																											
1	2014	Malibu	Body	Radio																																																										
1	2014	Malibu	Body	Digital Radio Receiver Control Module																																																											
1	2014	Malibu	Body	Multimedia Player Interface Module																																																											
1	2014	Malibu	Body	Mobile Telephone Control Module																																																											
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
1	2014	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2014	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2014	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
1	2014	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2014	Malibu	Body	Keyless Entry Control Module																																																										
1	2014	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2014	Malibu	Body	Parking Assist Control Module																																																										
1	2014	Malibu	Body	Frontview Camera Module																																																										
1	2014	Malibu	Body	Steering Column Lock Control Module																																																										
1	2015	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																										
1	2015	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																										
1	2015	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																										
1	2015	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																										
1	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																										
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																										
1	2015	Impala	Chassis	Electronic Brake Control Module																																																										
1	2015	Impala	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Impala	Chassis	Parking Brake Control Module																																																										
1	2015	Impala	Chassis	Power Steering Control Module																																																										
1	2015	Impala	Chassis	Power Steering Control Module																																																										
1	2015	Impala	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2015	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Impala	Body	Passenger Presence Module																																																										
1	2015	Impala	Body	Instrument Cluster																																																										
1	2015	Impala	Body	Radio Control																																																										
1	2015	Impala	Body	HVAC Control																																																										
1	2015	Impala	Body	Radio																																																										
1	2015	Impala	Body	Amplifier																																																										
1	2015	Impala	Body	Human Machine Interface Control Module																																																										
1	2015	Impala	Body	Telematics Communication Interface Control Module																																																										
1	2015	Impala	Body	HVAC Control Module																																																										
1	2015	Impala	Body	Keyless Entry Control Module																																																										
1	2015	Impala	Body	Right Side Object Detection Control Module																																																										
1	2015	Impala	Body	Left Side Object Detection Control Module																																																										
1	2015	Impala	Body	Parking Assist Control Module																																																										
1	2015	Impala	Body	Frontview Camera Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Chassis Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBS Chassis Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2015	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																										
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																										
1	2015	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.4L LE9 Chassis Control Module																																																										
1	2015	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2015	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																										
1	2015	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																										
1	2015	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																										
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																										
1	2015	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																										
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	3.0L LFW Chassis Control Module																																																										
1	2015	Malibu	Powertrain	3.0L LFW Transmission Control Module																																																										
1	2015	Malibu	Powertrain	Rear Differential Clutch Control Module																																																										
1	2015	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2015	Malibu	Chassis	Parking Brake Control Module																																																										
1	2015	Malibu	Chassis	Power Steering Control Module																																																										
1	2015	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																									V																
1	2015	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																									V																
1	2015	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Malibu	Body	Passenger Presence Module																																																										
1	2015	Malibu	Body	Instrument Cluster																																																										
1	2015	Malibu	Body	Headlamp Control Module																																																										
1	2015	Malibu	Body	Radio																																																									
1	2015	Malibu	Body	Digital Radio Receiver Control Module																																																										
1	2015	Malibu	Body	Multimedia Player Interface Module																																																										
1	2015	Malibu	Body	Mobile Telephone Control Module																																																										
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
1	2015	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
1	2015	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2015	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
1	2015	Malibu	Body	Front Seat Heating Control Module																																																										
1	2015	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2015	Malibu	Body	Keyless Entry Control Module																																																										
1	2015	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2015	Malibu	Body	Parking Assist Control Module																																																										
1	2015	Malibu	Body	Frontview Camera Module																																																										
1	2015	Malibu	Body	Steering Column Lock Control Module																																																										
1	2015	Malibu (LSG)	Powertrain	1.6L LLU Engine Control Module																														V															V					V						
1	2015	Malibu (LSG)	Powertrain	Transmission Control Module																																																									
1	2015	Malibu (LSG)	Powertrain	Rear Differential Clutch Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2015	Malibu (LSG)	Chassis	Electronic Brake Control Module																																																										
1	2015	Malibu (LSG)	Chassis	Parking Brake Control Module																																																										
1	2015	Malibu (LSG)	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Malibu (LSG)	Chassis	Suspension Control Module																																																										
1	2015	Malibu (LSG)	Body	Body Control Module																																																										
1	2015	Malibu (LSG)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Malibu (LSG)	Body	Instrument Cluster																																																										
1	2015	Malibu (LSG)	Body	Headlamp Control Module																																																										
1	2015	Malibu (LSG)	Body	Radio																																																										
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Malibu (LSG)	Body	HVAC Control Module																																																										
1	2015	Malibu (LSG)	Body	Front Seat Heating Control Module																																																										
1	2015	Malibu (LSG)	Body	Keyless Entry Control Module																																																										
1	2015	Malibu (LSG)	Body	Left Side Object Detection Control Module																																																										
1	2015	Malibu (LSG)	Body	Parking Assist Control Module																																																										
1	2015	Malibu (LSG)	Body	Frontview Camera Module																																																										
1	2015	Malibu (LSG)	Body	Steering Column Lock Control Module																																																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2016	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																										
1	2016	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																										
1	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2016	Impala	Powertrain	Chassis Control Module																																																										
1	2016	Impala	Chassis	Electronic Brake Control Module																																																										
1	2016	Impala	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Impala	Chassis	Parking Brake Control Module																																																										
1	2016	Impala	Chassis	Power Steering Control Module																																																										
1	2016	Impala	Chassis	Power Steering Control Module																																																										
1	2016	Impala	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2016	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Impala	Body	Passenger Presence Module																																																										
1	2016	Impala	Body	Instrument Cluster																																																										
1	2016	Impala	Body	Radio Control																																																										
1	2016	Impala	Body	HVAC Control																																																										
1	2016	Impala	Body	Radio																																																										
1	2016	Impala	Body	Amplifier																																																										
1	2016	Impala	Body	Human Machine Interface Control Module																																																										
1	2016	Impala	Body	Navigation Control Module																																																										
1	2016	Impala	Body	Telematics Communication Interface Control Module																																																										
1	2016	Impala	Body	HVAC Control Module																																																										
1	2016	Impala	Body	Seat Memory Control Module - Driver																																																										
1	2016	Impala	Body	Keyless Entry Control Module																																																										
1	2016	Impala	Body	Right Side Object Detection Control Module																																																										
1	2016	Impala	Body	Left Side Object Detection Control Module																																																										
1	2016	Impala	Body	Parking Assist Control Module																																																										
1	2016	Impala	Body	Frontview Camera Module																																																										
1	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2016	Malibu	Powertrain	Fuel Injector Control Module																																																										
1	2016	Malibu	Powertrain	Chassis Control Module																																																										
1	2016	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2016	Malibu	Chassis	Parking Brake Control Module																																																										
1	2016	Malibu	Chassis	Power Steering Control Module																																																										
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Malibu	Body	Passenger Presence Module																																																										
1	2016	Malibu	Body	Instrument Cluster																																																										
1	2016	Malibu	Body	Headlamp Control Module																																																										
1	2016	Malibu	Body	Radio																																																									
1	2016	Malibu	Body	Digital Radio Receiver Control Module																																																									
1	2016	Malibu	Body	Multimedia Player Interface Module																																																									
1	2016	Malibu	Body	Mobile Telephone Control Module																																																									
1	2016	Malibu	Body	Telematics Communication Interface Control Module																																																									
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																									
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																									
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																									
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																									
1	2016	Malibu	Body	Seat Memory Control Module																																																									
1	2016	Malibu	Body	Front Seat Heating Control Module																																																									
1	2016	Malibu	Body	Rear Seat Heating Control Module																																																									
1	2016	Malibu	Body	Keyless Entry Control Module																																																									
1	2016	Malibu	Body	Left Side Object Detection Control Module																																																									
1	2016	Malibu	Body	Parking Assist Control Module																																																									
1	2016	Malibu	Body	Frontview Camera Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2005	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																											
A	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																											
A	2005	ALL	Powertrain	Transmission Control Module																																																											
A	2005	ALL	Chassis	Power Steering Control Module																																																											
A	2005	ALL	Chassis	Anti-lock Brake System																																																											
A	2005	ALL	Body	Body Control Module																																																										
A	2005	ALL	Body	Digital Radio Receiver																																																										
A	2005	ALL	Body	Instrument Panel																																																										
A	2005	ALL	Body	Radio																																																										
A	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2006	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																										
A	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
A	2006	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																										
A	2006	ALL	Powertrain	Transmission Control Module																																																										
A	2006	ALL	Chassis	Power Steering Control Module																																																										
A	2006	ALL	Chassis	Anti-lock Brake System																																																										
A	2006	ALL	Body	Body Control Module																																																									
A	2006	ALL	Body	Digital Radio Receiver																																																										
A	2006	ALL	Body	Instrument Panel																																																										
A	2006	ALL	Body	Radio																																																										
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2006	ALL	Body	Theft Deterrent Module																																																										
A	2007	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																										
A	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
A	2007	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																										
A	2007	ALL	Powertrain	Transmission Control Module																																																										
A	2007	ALL	Chassis	Power Steering Control Module																																																										
A	2007	ALL	Chassis	Electronic Brake Control Module																																																										
A	2007	ALL	Body	Body Control Module																																																										
A	2007	ALL	Body	Digital Radio Receiver																																																										
A	2007	ALL	Body	Instrument Panel Cluster																																																										
A	2007	ALL	Body	Passenger Presence System																																																										
A	2007	ALL	Body	Personal Audio Link Module																																																										
A	2007	ALL	Body	Radio																																																										
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2007	ALL	Body	Theft Deterrent Module																																																										
A	2008	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
A	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																										
A	2008	ALL	Powertrain	Transmission Control Module																																																										
A	2008	ALL	Chassis	Power Steering Control Module																																																										
A	2008	ALL	Chassis	Electronic Brake Control Module with VSES																																																										
A	2008	ALL	Chassis	Electronic Brake Control Module without VSES																																																										
A	2008	ALL	Body	Body Control Module																																																										
A	2008	ALL	Body	Digital Radio Receiver																																																										
A	2008	ALL	Body	Instrument Panel Cluster																																																										
A	2008	ALL	Body	Passenger Presence System																																																										
A	2008	ALL	Body	Personal Audio Link Module																																																										
A	2008	ALL	Body	Radio																																																										
A	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2008	ALL	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2009	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																											
A	2009	ALL	Powertrain	(H)2.2L L4 LAP Engine Control Module																																																											
A	2009	ALL	Powertrain	Transmission Control Module																																																											
A	2009	ALL	Chassis	Power Steering Control Module																																																											
A	2009	ALL	Chassis	Electronic Brake Control Module with VSES																																																											
A	2009	ALL	Chassis	Electronic Brake Control Module without VSES																																																											
A	2009	ALL	Body	Body Control Module																																																											
A	2009	ALL	Body	Digital Radio Receiver																																																											
A	2009	ALL	Body	Instrument Panel Cluster																																																											
A	2009	ALL	Body	Passenger Presence System																																																											
A	2009	ALL	Body	Personal Audio Link Module																																																											
A	2009	ALL	Body	Radio																																																											
A	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
A	2009	ALL	Body	Theft Deterrent Module																																																											
A	2010	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																											
A	2010	ALL	Powertrain	(5)2.2L L4 LAP Engine Control Module																																																											
A	2010	ALL	Powertrain	Transmission Control Module																																																											
A	2010	ALL	Chassis	Power Steering Control Module																																																											
A	2010	ALL	Chassis	Electronic Brake Control Module with VSES																																																											
A	2010	ALL	Chassis	Electronic Brake Control Module without VSES																																																											
A	2010	ALL	Body	Body Control Module																																																											
A	2010	ALL	Body	Digital Radio Receiver																																																											
A	2010	ALL	Body	Driver Information Center																																																											
A	2010	ALL	Body	Instrument Panel Cluster																																																											
A	2010	ALL	Body	Passenger Presence System																																																											
A	2010	ALL	Body	Personal Audio Link Module																																																											
A	2010	ALL	Body	Radio																																																											
A	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
A	2010	ALL	Body	Theft Deterrent Module																																																											
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
A	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																											
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
A	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																											
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
A	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
A	2012	Cobalt	Chassis	Electronic Brake Control Module																																																											
A	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																											
A	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2012	Cobalt	Body	Body Control Module																																																											
A	2012	Cobalt	Body	Passenger Presence Module																																																											
A	2012	Cobalt	Body	Instrument Cluster																																																											
A	2012	Cobalt	Body	Radio																																																											
A	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																											
A	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																											
A	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
A	2012	Cobalt	Body	Front Seat Heating Control Module																																																											
A	2012	Cobalt	Body	Parking Assist Control Module																																																											
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
A	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
A	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
A	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
A	2013	Cobalt	Chassis	Electronic Brake Control Module																																																											
A	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2013	Cobalt	Body	Body Control Module																																																											
A	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2013	Cobalt	Body	Instrument Cluster																																																											
A	2013	Cobalt	Body	Radio																																																											
A	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																											
A	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											
A	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
A	2013	Cobalt	Body	Front Seat Heating Control Module																																																											
A	2013	Cobalt	Body	Parking Assist Control Module																																																											
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
A	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
A	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
A	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
A	2014	Cobalt	Chassis	Electronic Brake Control Module																																																											
A	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2014	Cobalt	Body	Body Control Module																																																											
A	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2014	Cobalt	Body	Instrument Cluster																																																											
A	2014	Cobalt	Body	Radio																																																											
A	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2014	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2014	Cobalt	Body	Parking Assist Control Module																																																										
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2015	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	Cobalt	Body	Body Control Module																																																										
A	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	Cobalt	Body	Instrument Cluster																																																										
A	2015	Cobalt	Body	Radio																																																										
A	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																										
A	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
A	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
A	2015	Cobalt	Body	Front Seat Heating Control Module																																																										
A	2015	Cobalt	Body	Parking Assist Control Module																																																										
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
A	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
A	2016	Cobalt	Chassis	Electronic Brake Control Module																																																										
A	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	Cobalt	Body	Body Control Module																																																										
A	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	Cobalt	Body	Instrument Cluster																																																										
A	2016	Cobalt	Body	Radio Other																																																										
A	2016	Cobalt	Body	Radio (IOB)																																																										
A	2016	Cobalt	Body	Radio (UF7)																																																										
A	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																											
A	2016	Cobalt	Body	Front Seat Heating Control Module																																																											
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																										
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																										
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2010	Beat	Powertrain	Transmission Control Module																																																										
B	2010	Beat	Chassis	Electronic Brake Control Module																																																										
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2010	Beat	Chassis	Power Steering Control Module																																																										
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2010	Beat	Body	Instrument Cluster																																																										
B	2010	Beat	Body	Keyless Entry Control Module																																																										
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																										
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																										
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2011	Beat	Powertrain	Transmission Control Module																																																										
B	2011	Beat	Chassis	Electronic Brake Control Module																																																										
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2011	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2011	Beat	Body	Instrument Cluster																																																										
B	2011	Beat	Body	Keyless Entry Control Module																																																										
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2012	Beat	Powertrain	Transmission Control Module																																																										
B	2012	Beat	Chassis	Electronic Brake Control Module																																																										
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2012	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2012	Beat	Body	Instrument Cluster																																																										
B	2012	Beat	Body	Keyless Entry Control Module																																																										
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2013	Beat	Powertrain	Transmission Control Module																																																										
B	2013	Beat	Chassis	Electronic Brake Control Module																																																										
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2013	Beat	Chassis	Electric Power Steering Control Module																																																										
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2013	Beat	Body	Instrument Cluster																																																										
B	2013	Beat	Body	Keyless Entry Control Module																																																										
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2014	Beat	Powertrain	Transmission Control Module																																																										
B	2014	Beat	Powertrain	Fuel Injector Control Module																																																										
B	2014	Beat	Chassis	Electronic Brake Control Module																																																										
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
B	2014	Beat	Chassis	Power Steering Control Module																																																											
B	2014	Beat	Chassis	Steering Wheel Angle Sensor Module																																																											
B	2014	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
B	2014	Beat	Body	Instrument Cluster																																																										
B	2014	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2015	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2015	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2015	Beat	Powertrain	Transmission Control Module																																																										
B	2015	Beat	Powertrain	Fuel Injector Control Module																																																										
B	2015	Beat	Chassis	Electronic Brake Control Module																																																										
B	2015	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2015	Beat	Chassis	Power Steering Control Module																																																										
B	2015	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2015	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2015	Beat	Body	Instrument Cluster																																																										
B	2015	Beat	Body	Radio																																																										
B	2015	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2015	Beat	Body	Keyless Entry Control Module																																																										
B	2016	Beat	Powertrain	1.0L LEB Engine Control Module																																																										
B	2016	Beat	Powertrain	1.19L LC5 Engine Control Module																																																										
B	2016	Beat	Powertrain	Transmission Control Module																																																										
B	2016	Beat	Chassis	Electronic Brake Control Module																																																										
B	2016	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																										
B	2016	Beat	Chassis	Power Steering Control Module																																																										
B	2016	Beat	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2016	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2016	Beat	Body	Instrument Cluster																																																										
B	2016	Beat	Body	Radio																																																										
B	2016	Beat	Body	Telematics Communication Interface Control Module																																																										
B	2016	Beat	Body	HVAC Control Module																																																										
B	2016	Beat	Body	Keyless Entry Control Module																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																										
B	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																										
B	2016	Cruze	Chassis	Electronic Brake Control Module																																																										
B	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																										
B	2016	Cruze	Chassis	Power Steering Control Module																																																										
B	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
B	2016	Cruze	Body	Body Control Module																																																										
B	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
B	2016	Cruze	Body	Passenger Presence Module																																																										
B	2016	Cruze	Body	Instrument Cluster																																																										
B	2016	Cruze	Body	Radio Controls																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
B	2016	Cruze	Body	HVAC Controls																																																												
B	2016	Cruze	Body	Trailer Interface Control Module																																																												
B	2016	Cruze	Body	Radio Base (IO3 IO7)																																																												
B	2016	Cruze	Body	Radio (IOA)																																																												
B	2016	Cruze	Body	Radio (IOB)																																																												
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																												
B	2016	Cruze	Body	Amplifier																																																												
B	2016	Cruze	Body	Multimedia Player Interface Module																																																												
B	2016	Cruze	Body	Human Machine Interface Control Module																																																												
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																												
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																												
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																												
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																												
B	2016	Cruze	Body	Keyless Entry Control Module																																																												
B	2016	Cruze	Body	Right Side Object Detection Control Module																																																												
B	2016	Cruze	Body	Left Side Object Detection Control Module																																																												
B	2016	Cruze	Body	Parking Assist Control Module																																																												
B	2016	Cruze	Body	Frontview Camera Module																																																												
B	2016	Cruze	Body	Steering Column Lock Control Module																																																												
B	2016	Cruze	Body	Long Range Radar Sensor Module																																																												
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
C	2010	Spark	Powertrain	Transmission Control Module																																																												
C	2010	Spark	Chassis	Electronic Brake Control Module																																																												
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2010	Spark	Chassis	Electric Power Steering Control Module																																																												
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2010	Spark	Body	Passenger Presence Module																																																												
C	2010	Spark	Body	Instrument Cluster																																																												
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																												
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																												
C	2011	Spark	Powertrain	Transmission Control Module																																																												
C	2011	Spark	Chassis	Electronic Brake Control Module																																																												
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2011	Spark	Chassis	Electric Power Steering Control Module																																																												
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2011	Spark	Body	Passenger Presence Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2011	Spark	Body	Instrument Cluster																																																												
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																												
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																												
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																												
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																												
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																												
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																												
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																												
C	2012	Spark	Powertrain	Transmission Control Module																																																												
C	2012	Spark	Chassis	Electronic Brake Control Module																																																												
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2012	Spark	Chassis	Electric Power Steering Control Module																																																												
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2012	Spark	Body	Passenger Presence Module																																																												
C	2012	Spark	Body	Instrument Cluster																																																												
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																												
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																												
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																												
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																												
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																												
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
C	2013	Spark	Powertrain	Fuel Injector Control Module																																																												
C	2013	Spark	Chassis	Electronic Brake Control Module																																																												
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2013	Spark	Chassis	Power Steering Control Module																																																												
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2013	Spark	Body	Body Control Module																																																												
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2013	Spark	Body	Passenger Presence Module																																																												
C	2013	Spark	Body	Instrument Cluster																																																												
C	2013	Spark	Body	Radio																																																												
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																												
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																												
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																												
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																												
C	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
C	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
C	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																												
C	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																												
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
C	2014	Spark	Powertrain	Fuel Injector Control Module																																																												
C	2014	Spark	Chassis	Electronic Brake Control Module																																																												
C	2014	Spark	Chassis	Electronic Brake Control Module																																																												
C	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
C	2014	Spark	Chassis	Power Steering Control Module																																																												
C	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2014	Spark	Body	Body Control Module																																																											
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Spark	Body	Passenger Presence Module																																																												
C	2014	Spark	Body	Instrument Cluster																																																											
C	2014	Spark	Body	Radio																																																											
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2014	Spark	Body	Keyless Entry Control Module																																																											
C	2014	Spark EV	Powertrain	Engine Control Module																																																											
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
C	2014	Spark EV	Powertrain	Drive Motor Control Module																																																											
C	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
C	2014	Spark EV	Chassis	Electronic Brake Control Module																																																											
C	2014	Spark EV	Chassis	Parking Brake Control Module																																																											
C	2014	Spark EV	Chassis	Power Steering Control Module																																																											
C	2014	Spark EV	Body	Body Control Module																																																											
C	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
C	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Spark EV	Body	Passenger Presence Module																																																											
C	2014	Spark EV	Body	Instrument Cluster																																																											
C	2014	Spark EV	Body	Radio																																																										
C	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2014	Spark EV	Body	HVAC Control Module																																																											
C	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																											
C	2014	Spark EV	Body	Coolant Heater Control Module																																																											
C	2014	Spark EV	Body	Keyless Entry Control Module																																																											
C	2014	Spark EV	Body	Battery Charger Control Module																																																											
C	2014	Spark EV	Body	DC Charging Control Module																																																											
C	2014	Spark EV	Body	Battery Energy Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
C	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Spark	Chassis	Power Steering Control Module																																																										
C	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Spark	Body	Body Control Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Passenger Presence Module																																																										
C	2015	Spark	Body	Instrument Cluster																																																										
C	2015	Spark	Body	Instrument Cluster																																																										
C	2015	Spark	Body	Tire Pressure Indicator Module																																																										
C	2015	Spark	Body	Radio																																																										
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Spark	Body	Keyless Entry Control Module																																																										
C	2015	Spark EV	Powertrain	Engine Control Module																																																										
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
C	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
C	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
C	2015	Spark EV	Chassis	Power Steering Control Module																																																										
C	2015	Spark EV	Body	Body Control Module																																																										
C	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark EV	Body	Passenger Presence Module																																																										
C	2015	Spark EV	Body	Instrument Cluster																																																										
C	2015	Spark EV	Body	Radio																																																										
C	2015	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2015	Spark EV	Body	Coolant Heater Control Module																																																											
C	2015	Spark EV	Body	Keyless Entry Control Module																																																											
C	2015	Spark EV	Body	Battery Charger Control Module																																																											
C	2015	Spark EV	Body	DC Charging Control Module																																																											
C	2015	Spark EV	Body	Battery Energy Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
C	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																											
C	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																											
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																											
C	2016	Spark	Powertrain	Fuel Injector Control Module																																																											
C	2016	Spark	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2016	Spark	Chassis	Power Steering Control Module																																																											
C	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Spark	Body	Body Control Module																																																											
C	2016	Spark	Body	Body Control Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Spark	Body	Instrument Cluster																																																											
C	2016	Spark	Body	Instrument Cluster																																																											
C	2016	Spark	Body	Radio																																																											
C	2016	Spark	Body	Telematics Communication Interface Control Module																																																											
C	2016	Spark	Body	Keyless Entry Control Module																																																											
C	2016	Spark EV	Powertrain	Engine Control Module																																																											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
C	2016	Spark EV	Powertrain	Drive Motor Control Module																																																											
C	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
C	2016	Spark EV	Chassis	Electronic Brake Control Module																																																											
C	2016	Spark EV	Chassis	Parking Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2016	Spark EV	Chassis	Power Steering Control Module																																																											
C	2016	Spark EV	Body	Body Control Module																																																											
C	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Spark EV	Body	Passenger Presence Module																																																										
C	2016	Spark EV	Body	Instrument Cluster																																																										
C	2016	Spark EV	Body	Radio																																																									
C	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																										
C	2016	Spark EV	Body	HVAC Control Module																																																										
C	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																										
C	2016	Spark EV	Body	Coolant Heater Control Module																																																										
C	2016	Spark EV	Body	Keyless Entry Control Module																																																										
C	2016	Spark EV	Body	Frontview Camera Module																																																										
C	2016	Spark EV	Body	Battery Charger Control Module																																																										
C	2016	Spark EV	Body	DC Charging Control Module																																																										
C	2016	Spark EV	Body	Battery Energy Control Module																																																										
D	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
D	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2010	Spark	Powertrain	Transmission Control Module																																																										
D	2010	Spark	Chassis	Electronic Brake Control Module																																																										
D	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2010	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2010	Spark	Body	Passenger Presence Module																																																										
D	2010	Spark	Body	Instrument Cluster																																																										
D	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										
D	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
D	2011	Spark	Powertrain	Transmission Control Module																																																										
D	2011	Spark	Chassis	Electronic Brake Control Module																																																										
D	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2011	Spark	Chassis	Electric Power Steering Control Module																																																										
D	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2011	Spark	Body	Passenger Presence Module																																																										
D	2011	Spark	Body	Instrument Cluster																																																										
D	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
D	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
D	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
D	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
D	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																											
D	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																											
D	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																											
D	2012	Spark	Powertrain	Transmission Control Module																																																											
D	2012	Spark	Chassis	Electronic Brake Control Module																																																											
D	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2012	Spark	Chassis	Electric Power Steering Control Module																																																											
D	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2012	Spark	Body	Passenger Presence Module																																																											
D	2012	Spark	Body	Instrument Cluster																																																											
D	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
D	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
D	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																											
D	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																											
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
D	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
D	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																											
D	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																											
D	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
D	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2013	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2013	Spark	Chassis	Electronic Brake Control Module																																																											
D	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2013	Spark	Chassis	Power Steering Control Module																																																											
D	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2013	Spark	Body	Body Control Module																																																											
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2013	Spark	Body	Passenger Presence Module																																																											
D	2013	Spark	Body	Instrument Cluster																																																											
D	2013	Spark	Body	Radio																																																											
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
D	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
D	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																											
D	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
D	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
D	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
D	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
D	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
D	2014	Spark	Chassis	Electronic Brake Control Module																																																										
D	2014	Spark	Chassis	Electronic Brake Control Module																																																										
D	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
D	2014	Spark	Chassis	Power Steering Control Module																																																										
D	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
D	2014	Spark	Body	Body Control Module																																																										
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	Spark	Body	Passenger Presence Module																																																										
D	2014	Spark	Body	Instrument Cluster																																																										
D	2014	Spark	Body	Radio																																																										
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2014	Spark	Body	Keyless Entry Control Module																																																										
D	2014	Spark EV	Powertrain	Engine Control Module																																																										
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
D	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
D	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
D	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
D	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
D	2014	Spark EV	Chassis	Power Steering Control Module																																																										
D	2014	Spark EV	Body	Body Control Module																																																										
D	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
D	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
D	2014	Spark EV	Body	Passenger Presence Module																																																										
D	2014	Spark EV	Body	Instrument Cluster																																																										
D	2014	Spark EV	Body	Radio																																																										
D	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
D	2014	Spark EV	Body	HVAC Control Module																																																										
D	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																										
D	2014	Spark EV	Body	Coolant Heater Control Module																																																										
D	2014	Spark EV	Body	Keyless Entry Control Module																																																										
D	2014	Spark EV	Body	Battery Charger Control Module																																																										
D	2014	Spark EV	Body	DC Charging Control Module																																																										
D	2014	Spark EV	Body	Battery Energy Control Module																																																										
D	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
D	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
D	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
D	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																											
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																												
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																												
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																												
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																												
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																												
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																												
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																												
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																												
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																												
D	2015	Spark	Powertrain	Fuel Injector Control Module																																																												
D	2015	Spark	Chassis	Electronic Brake Control Module																																																												
D	2015	Spark	Chassis	Electronic Brake Control Module																																																												
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																												
D	2015	Spark	Chassis	Power Steering Control Module																																																												
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																												
D	2015	Spark	Body	Body Control Module																																																											
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
D	2015	Spark	Body	Passenger Presence Module																																																												
D	2015	Spark	Body	Instrument Cluster																																																											
D	2015	Spark	Body	Instrument Cluster																																																											
D	2015	Spark	Body	Tire Pressure Indicator Module																																																											
D	2015	Spark	Body	Radio																																																											
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
D	2015	Spark	Body	Keyless Entry Control Module																																																											
D	2015	Spark EV	Powertrain	Engine Control Module																																																											
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
D	2015	Spark EV	Powertrain	Drive Motor Control Module																																																											
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
D	2015	Spark EV	Chassis	Electronic Brake Control Module																																																											
D	2015	Spark EV	Chassis	Parking Brake Control Module																																																											
D	2015	Spark EV	Chassis	Power Steering Control Module																																																											
D	2015	Spark EV	Body	Body Control Module																																																											
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2015	Spark EV	Body	Passenger Presence Module																																																											
D	2015	Spark EV	Body	Instrument Cluster																																																											
D	2015	Spark EV	Body	Radio																																																											
D	2015	Spark EV	Body	HVAC Control Module																																																											
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																											
D	2015	Spark EV	Body	Coolant Heater Control Module																																																											
D	2015	Spark EV	Body	Keyless Entry Control Module																																																											
D	2015	Spark EV	Body	Battery Charger Control Module																																																											
D	2015	Spark EV	Body	DC Charging Control Module																																																											
D	2015	Spark EV	Body	Battery Energy Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
D	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
D	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																											
D	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
D	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
D	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																											
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																											
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																											
D	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
D	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
D	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
D	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																											
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																											
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																											
D	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																											
D	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																											
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																											
D	2016	Spark	Powertrain	Fuel Injector Control Module																																																											
D	2016	Spark	Chassis	Electronic Brake Control Module																																																											
D	2016	Spark	Chassis	Electronic Brake Control Module																																																											
D	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
D	2016	Spark	Chassis	Power Steering Control Module																																																											
D	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
D	2016	Spark	Body	Body Control Module																																																										
D	2016	Spark	Body	Body Control Module																																																										
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2016	Spark	Body	Instrument Cluster																																																										
D	2016	Spark	Body	Instrument Cluster																																																										
D	2016	Spark	Body	Radio																																																										
D	2016	Spark	Body	Telematics Communication Interface Control Module																																																											
D	2016	Spark	Body	Keyless Entry Control Module																																																											
D	2016	Spark EV	Powertrain	Engine Control Module																																																											
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
D	2016	Spark EV	Powertrain	Drive Motor Control Module																																																											
D	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
D	2016	Spark EV	Chassis	Electronic Brake Control Module																																																											
D	2016	Spark EV	Chassis	Parking Brake Control Module																																																											
D	2016	Spark EV	Chassis	Power Steering Control Module																																																											
D	2016	Spark EV	Body	Body Control Module																																																											
D	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
D	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
D	2016	Spark EV	Body	Passenger Presence Module																																																											
D	2016	Spark EV	Body	Instrument Cluster																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
D	2016	Spark EV	Body	Radio																																																												
D	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																												
D	2016	Spark EV	Body	HVAC Control Module																																																												
D	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																												
D	2016	Spark EV	Body	Coolant Heater Control Module																																																												
D	2016	Spark EV	Body	Keyless Entry Control Module																																																												
D	2016	Spark EV	Body	Frontview Camera Module																																																												
D	2016	Spark EV	Body	Battery Charger Control Module																																																												
D	2016	Spark EV	Body	DC Charging Control Module																																																												
D	2016	Spark EV	Body	Battery Energy Control Module																																																												
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Automatic Transmission																																																												
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Manual Transmission																																																												
F	2010	Camaro	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																												
F	2010	Camaro	Powertrain	(V) 3.6L LLT Transmission Control Module																																																												
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2010	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																												
F	2010	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																												
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2010	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2010	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2010	Camaro	Chassis	Power Steering Control Module																																																												
F	2010	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2010	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2010	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2010	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2010	Camaro	Body	Passenger Presence Module																																																												
F	2010	Camaro	Body	Instrument Cluster																																																												
F	2010	Camaro	Body	Auxiliary Gage Module																																																												
F	2010	Camaro	Body	Radio																																																												
F	2010	Camaro	Body	Multimedia Player Interface Module																																																												
F	2010	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																												
F	2010	Camaro	Body	Mobile Telephone Control Module																																																												
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2010	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																												
F	2010	Camaro	Body	Front Seat Heating Control Module																																																												
F	2010	Camaro	Body	Folding Top Control Module																																																												
F	2010	Camaro	Body	Parking Assist Control Module																																																												
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Automatic Transmission																																																												
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Manual Transmission																																																												
F	2011	Camaro	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																												
F	2011	Camaro	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2011	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																												
F	2011	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																												
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2011	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2011	Camaro	Chassis	Power Steering Control Module																																																												
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2011	Camaro	Body	Passenger Presence Module																																																												
F	2011	Camaro	Body	Instrument Cluster																																																												
F	2011	Camaro	Body	Head-Up Display Module																																																												
F	2011	Camaro	Body	Auxiliary Gage Module																																																												
F	2011	Camaro	Body	Headlamp Control Module																																																												
F	2011	Camaro	Body	Radio																																																												
F	2011	Camaro	Body	Multimedia Player Interface Module																																																												
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																												
F	2011	Camaro	Body	Mobile Telephone Control Module																																																												
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																												
F	2011	Camaro	Body	Front Seat Heating Control Module																																																												
F	2011	Camaro	Body	Folding Top Control Module																																																												
F	2011	Camaro	Body	Parking Assist Control Module																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module																																																												
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																												
F	2012	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2012	Camaro	Chassis	Power Steering Control Module																																																												
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2012	Camaro	Chassis	Suspension Control Module																																																												
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2012	Camaro	Body	Passenger Presence Module																																																												
F	2012	Camaro	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
F	2012	Camaro	Body	Head-Up Display Module																																																											
F	2012	Camaro	Body	Auxiliary Gage Module																																																												
F	2012	Camaro	Body	Headlamp Control Module																																																												
F	2012	Camaro	Body	Radio																																																												
F	2012	Camaro	Body	Multimedia Player Interface Module																																																												
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																												
F	2012	Camaro	Body	Mobile Telephone Control Module																																																												
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																												
F	2012	Camaro	Body	Front Seat Heating Control Module																																																												
F	2012	Camaro	Body	Folding Top Control Module																																																												
F	2012	Camaro	Body	Parking Assist Control Module																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow																																																												
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																												
F	2013	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																												
F	2013	Camaro	Chassis	Power Steering Control Module																																																												
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2013	Camaro	Chassis	Suspension Control Module																																																												
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2013	Camaro	Body	Passenger Presence Module																																																												
F	2013	Camaro	Body	Instrument Cluster																																																												
F	2013	Camaro	Body	Head-Up Display Module																																																												
F	2013	Camaro	Body	Auxiliary Gage Module																																																												
F	2013	Camaro	Body	Headlamp Control Module																																																												
F	2013	Camaro	Body	Radio																																																											
F	2013	Camaro	Body	Multimedia Player Interface Module																																																												
F	2013	Camaro	Body	Mobile Telephone Control Module																																																												
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																												
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
F	2013	Camaro	Body	HVAC Control Module																																																											
F	2013	Camaro	Body	Front Seat Heating Control Module																																																											
F	2013	Camaro	Body	Folding Top Control Module																																																											
F	2013	Camaro	Body	Parking Assist Control Module																																																											
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																											
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																											
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																											
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																											
F	2014	Camaro	Powertrain	Transmission Control Module																																																											
F	2014	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2014	Camaro	Chassis	Parking Brake Control Module																																																											
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2014	Camaro	Chassis	Power Steering Control Module																																																											
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2014	Camaro	Chassis	Suspension Control Module																																																											
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2014	Camaro	Body	Passenger Presence Module																																																											
F	2014	Camaro	Body	Instrument Cluster																																																											
F	2014	Camaro	Body	Head-Up Display Module																																																											
F	2014	Camaro	Body	Auxiliary Gage Module																																																											
F	2014	Camaro	Body	Headlamp Control Module																																																											
F	2014	Camaro	Body	Radio																																																											
F	2014	Camaro	Body	Mobile Telephone Control Module																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2014	Camaro	Body	HVAC Control Module																																																											
F	2014	Camaro	Body	Front Seat Heating Control Module																																																											
F	2014	Camaro	Body	Folding Top Control Module																																																											
F	2014	Camaro	Body	Parking Assist Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module																																																											
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2014	SS	Powertrain	Chassis Control Module																																																											
F	2014	SS	Chassis	Electronic Brake Control Module																																																											
F	2014	SS	Chassis	Parking Brake Control Module																																																											
F	2014	SS	Chassis	Power Steering Control Module																																																											
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2014	SS	Body	Body Control Module																																																											
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2014	SS	Body	Passenger Presence Module																																																											
F	2014	SS	Body	Instrument Cluster																																																											
F	2014	SS	Body	Head-Up Display Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
F	2014	SS	Body	Radio Control																																																											
F	2014	SS	Body	HVAC Control																																																											
F	2014	SS	Body	Headlamp Control Module																																																											
F	2014	SS	Body	Trailer Interface Control Module																																																											
F	2014	SS	Body	Radio																																																											
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9																																																											
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2014	SS	Body	HVAC Control Module																																																											
F	2014	SS	Body	Seat Memory Control Module - Driver																																																											
F	2014	SS	Body	Keyless Entry Control Module																																																											
F	2014	SS	Body	Right Side Object Detection Control Module																																																											
F	2014	SS	Body	Left Side Object Detection Control Module																																																											
F	2014	SS	Body	Parking Assist Control Module																																																											
F	2014	SS	Body	Frontview Camera Module																																																											
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																											
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																											
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																											
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																											
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																											
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																											
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																											
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																											
F	2015	Camaro	Powertrain	Transmission Control Module																																																											
F	2015	Camaro	Chassis	Electronic Brake Control Module																																																											
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																											
F	2015	Camaro	Chassis	Power Steering Control Module																																																											
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																											
F	2015	Camaro	Chassis	Suspension Control Module																																																											
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
F	2015	Camaro	Body	Passenger Presence Module																																																											
F	2015	Camaro	Body	Instrument Cluster																																																											
F	2015	Camaro	Body	Head-Up Display Module																																																											
F	2015	Camaro	Body	Auxiliary Gage Module																																																											
F	2015	Camaro	Body	Headlamp Control Module																																																											
F	2015	Camaro	Body	Radio																																																											
F	2015	Camaro	Body	Mobile Telephone Control Module																																																											
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6																																																											
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																											
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																											
F	2015	Camaro	Body	HVAC Control Module																																																											
F	2015	Camaro	Body	Front Seat Heating Control Module																																																											
F	2015	Camaro	Body	Folding Top Control Module																																																											
F	2015	Camaro	Body	Parking Assist Control Module																																																											
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																											
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																											
F	2015	SS	Powertrain	Fuel Injector Control Module																																																												
F	2015	SS	Powertrain	Chassis Control Module																																																												
F	2015	SS	Chassis	Electronic Brake Control Module																																																												
F	2015	SS	Chassis	Parking Brake Control Module																																																												
F	2015	SS	Chassis	Power Steering Control Module																																																												
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2015	SS	Chassis	Suspension Control Module																																																												
F	2015	SS	Body	Body Control Module																																																												
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2015	SS	Body	Passenger Presence Module																																																												
F	2015	SS	Body	Instrument Cluster																																																												
F	2015	SS	Body	Head-Up Display Module																																																												
F	2015	SS	Body	Radio Control																																																												
F	2015	SS	Body	HVAC Control																																																												
F	2015	SS	Body	Headlamp Control Module																																																												
F	2015	SS	Body	Trailer Interface Control Module																																																												
F	2015	SS	Body	Radio																																																												
F	2015	SS	Body	Telematics Communication Interface Control Module																																																												
F	2015	SS	Body	HVAC Control Module																																																												
F	2015	SS	Body	Seat Memory Control Module - Driver																																																												
F	2015	SS	Body	Keyless Entry Control Module																																																												
F	2015	SS	Body	Right Side Object Detection Control Module																																																												
F	2015	SS	Body	Left Side Object Detection Control Module																																																												
F	2015	SS	Body	Parking Assist Control Module																																																												
F	2015	SS	Body	Frontview Camera Module																																																												
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																												
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																												
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																												
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																												
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																												
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																												
F	2016	Camaro	Powertrain	Transmission Control Module																																																												
F	2016	Camaro	Chassis	Electronic Brake Control Module																																																												
F	2016	Camaro	Chassis	Parking Brake Control Module																																																												
F	2016	Camaro	Chassis	Power Steering Control Module																																																												
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																												
F	2016	Camaro	Chassis	Suspension Control Module																																																												
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
F	2016	Camaro	Body	Serial Data Gateway Module																																																												
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
F	2016	Camaro	Body	Passenger Presence Module																																																												
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																												
F	2016	Camaro	Body	Head-Up Display Module																																																												
F	2016	Camaro	Body	Auxiliary Gage Module																																																												
F	2016	Camaro	Body	Radio Controls																																																												
F	2016	Camaro	Body	HVAC Controls																																																												
F	2016	Camaro	Body	Vehicle Performance Data Recorder																																																												
F	2016	Camaro	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
F	2016	Camaro	Body	Amplifier																																																										
F	2016	Camaro	Body	Media Disc Player																																																										
F	2016	Camaro	Body	Human Machine Interface Control Module																																																										
F	2016	Camaro	Body	Navigation Control Module																																																										
F	2016	Camaro	Body	Mobile Telephone Control Module																																																										
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																										
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																										
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)																																																										
F	2016	Camaro	Body	Seat Memory Control Module - Driver																																																										
F	2016	Camaro	Body	Folding Top Control Module																																																										
F	2016	Camaro	Body	Keyless Entry Control Module																																																										
F	2016	Camaro	Body	Right Side Object Detection Control Module																																																										
F	2016	Camaro	Body	Left Side Object Detection Control Module																																																										
F	2016	Camaro	Body	Parking Assist Control Module																																																										
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																										
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																										
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																										
F	2016	SS	Powertrain	Fuel Injector Control Module																																																										
F	2016	SS	Chassis	Electronic Brake Control Module																																																										
F	2016	SS	Chassis	Parking Brake Control Module																																																										
F	2016	SS	Chassis	Power Steering Control Module																																																										
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module																																																										
F	2016	SS	Chassis	Suspension Control Module																																																										
F	2016	SS	Body	Body Control Module																																																										
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
F	2016	SS	Body	Passenger Presence Module																																																										
F	2016	SS	Body	Instrument Cluster																																																										
F	2016	SS	Body	Head-Up Display Module																																																										
F	2016	SS	Body	Radio Control																																																										
F	2016	SS	Body	HVAC Control																																																										
F	2016	SS	Body	Trailer Interface Control Module																																																										
F	2016	SS	Body	Radio																																																										
F	2016	SS	Body	Telematics Communication Interface Control Module																																																										
F	2016	SS	Body	HVAC Control Module																																																										
F	2016	SS	Body	Seat Memory Control Module - Driver																																																										
F	2016	SS	Body	Keyless Entry Control Module																																																										
F	2016	SS	Body	Right Side Object Detection Control Module																																																										
F	2016	SS	Body	Left Side Object Detection Control Module																																																										
F	2016	SS	Body	Parking Assist Control Module																																																										
F	2016	SS	Body	Frontview Camera Module																																																										
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																										
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
G	2016	Malibu	Powertrain	Fuel Injector Control Module																																																										
G	2016	Malibu	Powertrain	Chassis Control Module																																																										
G	2016	Malibu	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2016	Malibu	Chassis	Parking Brake Control Module																																																										
G	2016	Malibu	Chassis	Power Steering Control Module																																																											
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																											
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
G	2016	Malibu	Body	Passenger Presence Module																																																												
G	2016	Malibu	Body	Instrument Cluster																																																												
G	2016	Malibu	Body	Headlamp Control Module																																																												
G	2016	Malibu	Body	Radio																																																											
G	2016	Malibu	Body	Digital Radio Receiver Control Module																																																											
G	2016	Malibu	Body	Multimedia Player Interface Module																																																											
G	2016	Malibu	Body	Mobile Telephone Control Module																																																											
G	2016	Malibu	Body	Telematics Communication Interface Control Module																																																											
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																											
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																											
G	2016	Malibu	Body	Seat Memory Control Module																																																											
G	2016	Malibu	Body	Front Seat Heating Control Module																																																											
G	2016	Malibu	Body	Rear Seat Heating Control Module																																																											
G	2016	Malibu	Body	Keyless Entry Control Module																																																											
G	2016	Malibu	Body	Left Side Object Detection Control Module																																																											
G	2016	Malibu	Body	Parking Assist Control Module																																																											
G	2016	Malibu	Body	Frontview Camera Module																																																											
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																											
H	2010	Sail	Powertrain	Transmission Control Module																																																											
H	2010	Sail	Chassis	Electronic Brake Control Module																																																											
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																											
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																											
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																											
H	2011	Sail	Powertrain	Transmission Control Module																																																											
H	2011	Sail	Chassis	Electronic Brake Control Module																																																											
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																											
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																											
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																											
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																											
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
H	2012	Sail	Powertrain	Transmission Control Module																																																											
H	2012	Sail	Chassis	Electronic Brake Control Module																																																											
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	Transmission Control Module																																																										
H	2013	Sail	Chassis	Electronic Brake Control Module																																																										
H	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2014	Sail	Powertrain	Transmission Control Module																																																										
H	2014	Sail	Chassis	Electronic Brake Control Module																																																										
H	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																										
H	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																										
H	2015	Sail	Chassis	Electronic Brake Control Module																																																										
H	2015	Sail	Chassis	Power Steering Control Module																																																										
H	2015	Sail	Body	Body Control Module																																																										
H	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Sail	Body	Radio/HVAC Control																																																										
H	2015	Sail	Body	HVAC Control Module																																																										
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
H	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																										
H	2016	Sail	Chassis	Electronic Brake Control Module																																																										
H	2016	Sail	Chassis	Power Steering Control Module																																																										
H	2016	Sail	Body	Body Control Module																																																										
H	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Sail	Body	Radio/HVAC Control																																																										
H	2016	Sail	Body	Radio																																																										
H	2016	Sail	Body	HVAC Control Module																																																										
J	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
J	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
J	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
J	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
J	2004	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																										
J	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
J	2004	Optra	Body	Remote Function Actuation																																																										
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel																																																										
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel Transmission Control Module																																																										
J	2004	Cavalier	Chassis	Anti-lock Brake System																																																										
J	2004	Cavalier	Body	Body Control Module																																																										
J	2004	Cavalier	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2004	Cavalier	Body	Instrument Panel Cluster																																																											
J	2004	Cavalier	Body	Radio																																																											
J	2004	Cavalier	Body	Supplemental Inflatable Restraint																																																											
J	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																											
J	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
J	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																											
J	2005	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																											
J	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																											
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																											
J	2005	Optra	Body	Remote Function Actuation																																																											
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																											
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																											
J	2005	Cavalier	Chassis	Anti-lock Brake System																																																											
J	2005	Cavalier	Body	Body Control Module																																																											
J	2005	Cavalier	Body	Digital Radio Receiver																																																											
J	2005	Cavalier	Body	Instrument Panel Cluster																																																											
J	2005	Cavalier	Body	Radio																																																											
J	2005	Cavalier	Body	Supplemental Inflatable Restraint																																																											
J	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																											
J	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
J	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																											
J	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2006	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																											
J	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2006	ALL	Body	Remote Function Actuation																																																											
J	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
J	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																											
J	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
J	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																											
J	2007	ALL	Powertrain	4 Speed Automatic																																																											
J	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																											
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																											
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																											
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																											
J	2007	ALL	Chassis	Tire Pressure Monitor																																																											
J	2007	ALL	Body	Remote Function Actuation																																																											
J	2007	ALL	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
J	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
J	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																											
J	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																																																											
J	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																											
J	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2008	ALL	Chassis	Tire Pressure Monitor																																																											
J	2008	ALL	Body	Remote Function Actuation																																																											
J	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
J	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
J	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
J	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																											
J	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																											
J	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																											
J	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2009	ALL	Chassis	Tire Pressure Monitor																																																											
J	2009	ALL	Body	Remote Function Actuation																																																											
J	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																											
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																											
J	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																											
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																											
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																											
J	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																											
J	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																											
J	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																											
J	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																											
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																											
J	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																											
J	2010	Cruze	Chassis	Electronic Brake Control Module																																																											
J	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2010	Cruze	Body	Body Control Module																																																											
J	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2010	Cruze	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2010	Cruze	Body	Instrument Cluster																																																											
J	2010	Cruze	Body	Trailer Interface Control Module																																																												
J	2010	Cruze	Body	Radio																																																											
J	2010	Cruze	Body	Multimedia Player Interface Module																																																											
J	2010	Cruze	Body	Mobile Telephone Control Module																																																											
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
J	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
J	2010	Cruze	Body	Keyless Entry Control Module																																																											
J	2010	Cruze	Body	Parking Assist Control Module																																																											
J	2010	Cruze	Body	Steering Column Lock Control Module																																																											
J	2010	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2010	Other	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
J	2010	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2010	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																											
J	2010	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
J	2010	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2010	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2010	Other	Powertrain	Transmission Control Module 5 Speed																																																											
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2010	Other	Chassis	Tire Pressure Monitor																																																											
J	2010	Other	Body	Remote Function Actuation																																																											
J	2010	Other	Body	Supplemental Inflatable Restraint																																																											
J	2010	Other	Body	Supplemental Inflatable Restraint																																																											
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																											
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																											
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																											
J	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																											
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																											
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																											
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																											
J	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																											
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																											
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																											
J	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																											
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																											
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																											
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																											
J	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
J	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																											
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																												
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
J	2011	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2011	Cruze	Body	Body Control Module																																																												
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2011	Cruze	Body	Passenger Presence Module																																																												
J	2011	Cruze	Body	Instrument Cluster																																																												
J	2011	Cruze	Body	Trailer Interface Control Module																																																												
J	2011	Cruze	Body	Radio																																																											
J	2011	Cruze	Body	Multimedia Player Interface Module																																																												
J	2011	Cruze	Body	Mobile Telephone Control Module																																																												
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																												
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																												
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																												
J	2011	Cruze	Body	Keyless Entry Control Module																																																												
J	2011	Cruze	Body	Parking Assist Control Module																																																												
J	2011	Cruze	Body	Steering Column Lock Control Module																																																												
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																												
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																												
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																												
J	2011	Other	Powertrain	Transmission Control Module 5 Speed																																																												
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No																																																												
J	2011	Other	Chassis	Tire Pressure Monitor																																																												
J	2011	Other	Body	Remote Function Actuation																																																												
J	2011	Other	Body	Supplemental Inflatable Restraint																																																												
J	2011	Other	Body	Supplemental Inflatable Restraint																																																												
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2012	Aveo	Powertrain	Fuel Pump Control Module																																																												
J	2012	Aveo	Powertrain	Fuel Injector Control Module																																																												
J	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Aveo	Chassis	Electric Power Steering Control Module																																																												
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Aveo	Body	Body Control Module Hatchback																																																												
J	2012	Aveo	Body	Body Control Module Sedan																																																												
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2012	Aveo	Body	Passenger Presence Module																																																												
J	2012	Aveo	Body	Instrument Cluster																																																												
J	2012	Aveo	Body	Radio																																																											
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																												
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
J	2012	Aveo	Body	Front Seat Heating Control Module																																																												
J	2012	Aveo	Body	Parking Assist Control Module																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																												
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2012	Cobalt	Chassis	Electronic Brake Control Module																																																												
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																												
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Cobalt	Body	Body Control Module																																																												
J	2012	Cobalt	Body	Passenger Presence Module																																																												
J	2012	Cobalt	Body	Instrument Cluster																																																												
J	2012	Cobalt	Body	Radio																																																											
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																												
J	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																												
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
J	2012	Cobalt	Body	Front Seat Heating Control Module																																																												
J	2012	Cobalt	Body	Parking Assist Control Module																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																												
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																												
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																												
J	2012	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2012	Cruze	Body	Body Control Module Hatchback																																																												
J	2012	Cruze	Body	Body Control Module Sedan																																																												
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2012	Cruze	Body	Passenger Presence Module																																																												
J	2012	Cruze	Body	Instrument Cluster																																																												
J	2012	Cruze	Body	Trailer Interface Control Module																																																												
J	2012	Cruze	Body	Radio																																																											
J	2012	Cruze	Body	Multimedia Player Interface Module																																																											
J	2012	Cruze	Body	Mobile Telephone Control Module																																																											
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
J	2012	Cruze	Body	Keyless Entry Control Module																																																											
J	2012	Cruze	Body	Parking Assist Control Module																																																											
J	2012	Cruze	Body	Steering Column Lock Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																											
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																											
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																											
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																											
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																											
J	2012	Sonic (First Gen)	Body	Remote Function Actuation																																																											
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																											
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																											
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																											
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module Chassis Expansion CAN BUS																																																										
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module High Speed CAN Bus																																																										
J	2012	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																										
J	2012	Sonic (Second Gen)	Body	Body Control Module Sedan																																																										
J	2012	Sonic (Second Gen)	Body	Passenger Presence Module																																																										
J	2012	Sonic (Second Gen)	Body	Instrument Cluster																																																										
J	2012	Sonic (Second Gen)	Body	Radio																																																										
J	2012	Sonic (Second Gen)	Body	Telematic Vehicle Localization and Immobilization Control Module																																																										
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																										
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																										
J	2012	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																										
J	2012	Sonic (Second Gen)	Body	Parking Assist Control Module																																																										
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2013	Aveo	Powertrain	Fuel Pump Control Module																																																										
J	2013	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2013	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Aveo	Chassis	Electric Power Steering Control Module																																																										
J	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Aveo	Body	Body Control Module Hatchback																																																										
J	2013	Aveo	Body	Body Control Module Sedan																																																										
J	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Aveo	Body	Passenger Presence Module																																																										
J	2013	Aveo	Body	Instrument Cluster																																																										
J	2013	Aveo	Body	Radio																																																										
J	2013	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Aveo	Body	Front Seat Heating Control Module																																																										
J	2013	Aveo	Body	Parking Assist Control Module																																																										
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2013	Cobalt	Chassis	Electronic Brake Control Module																																																											
J	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2013	Cobalt	Body	Body Control Module																																																											
J	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2013	Cobalt	Body	Instrument Cluster																																																											
J	2013	Cobalt	Body	Radio																																																										
J	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																										
J	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2013	Cobalt	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
J	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																										
J	2013	Cruze	Chassis	Electronic Brake Control Module																																																										
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Cruze	Body	Body Control Module Hatchback																																																										
J	2013	Cruze	Body	Body Control Module Sedan																																																										
J	2013	Cruze	Body	Body Control Module Station Wagon																																																										
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Cruze	Body	Passenger Presence Module																																																										
J	2013	Cruze	Body	Instrument Cluster																																																										
J	2013	Cruze	Body	Trailer Interface Control Module																																																										
J	2013	Cruze	Body	Radio																																																										
J	2013	Cruze	Body	Digital Radio Receiver Control Module																																																										
J	2013	Cruze	Body	Multimedia Player Interface Module																																																										
J	2013	Cruze	Body	Mobile Telephone Control Module																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
J	2013	Cruze	Body	Front Seat Heating Control Module																																																										
J	2013	Cruze	Body	Keyless Entry Control Module																																																										
J	2013	Cruze	Body	Right Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Left Side Object Detection Control Module																																																										
J	2013	Cruze	Body	Parking Assist Control Module																																																										
J	2013	Cruze	Body	Steering Column Lock Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																										
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																										
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																												
J	2013	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																												
J	2013	Sonic (First Gen)	Body	Remote Function Actuation																																																												
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																												
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Fuel Pump Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Fuel Pump Control Module																																																												
J	2013	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																												
J	2013	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2013	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2013	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																												
J	2013	Sonic (Second Gen)	Body	Body Control Module Sedan																																																												
J	2013	Sonic (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2013	Sonic (Second Gen)	Body	Passenger Presence Module																																																												
J	2013	Sonic (Second Gen)	Body	Instrument Cluster																																																												
J	2013	Sonic (Second Gen)	Body	Radio																																																												
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																												
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																											
J	2013	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																											
J	2013	Sonic (Second Gen)	Body	Parking Assist Control Module																																																											
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2013	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2013	Spin	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2013	Spin	Chassis	Electronic Brake Control Module																																																											
J	2013	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2013	Spin	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2013	Spin	Body	Body Control Module																																																											
J	2013	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2013	Spin	Body	Instrument Cluster																																																											
J	2013	Spin	Body	Radio																																																											
J	2013	Spin	Body	HVAC Control Module Heater Only (C41)																																																											
J	2013	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2013	Spin	Body	HVAC Control Module Single Zone (C60)																																																											
J	2013	Spin	Body	Parking Assist Control Module																																																											
J	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																											
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																											
J	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																											
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																											
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																											
J	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																											
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
J	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																											
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
J	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	Chassis Control Module																																																										
J	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Aveo	Chassis	Power Steering Control Module																																																										
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Aveo	Body	Body Control Module Hatchback																																																										
J	2014	Aveo	Body	Body Control Module Sedan																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Instrument Cluster																																																										
J	2014	Aveo	Body	Radio																																																										
J	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Aveo	Body	Front Seat Heating Control Module																																																										
J	2014	Aveo	Body	Keyless Entry Control Module																																																										
J	2014	Aveo	Body	Parking Assist Control Module																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2014	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Cobalt	Body	Body Control Module																																																										
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Cobalt	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2014	Cobalt	Body	Radio																																																												
J	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Cobalt	Body	Front Seat Heating Control Module																																																												
J	2014	Cobalt	Body	Parking Assist Control Module																																																												
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																											
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																												
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																												
J	2014	Cruze	Powertrain	Fuel Injector Control Module																																																													
J	2014	Cruze	Chassis	Electronic Brake Control Module																																																													
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2014	Cruze	Chassis	Power Steering Control Module																																																													
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2014	Cruze	Body	Body Control Module Hatchback																																																													
J	2014	Cruze	Body	Body Control Module Sedan																																																													
J	2014	Cruze	Body	Body Control Module Station Wagon																																																													
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2014	Cruze	Body	Passenger Presence Module																																																													
J	2014	Cruze	Body	Instrument Cluster																																																													
J	2014	Cruze	Body	Trailer Interface Control Module																																																													
J	2014	Cruze	Body	Radio																																																													
J	2014	Cruze	Body	Digital Radio Receiver Control Module																																																													
J	2014	Cruze	Body	Multimedia Player Interface Module																																																													
J	2014	Cruze	Body	Mobile Telephone Control Module																																																													
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																													
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																													
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																													
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																													
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																													
J	2014	Cruze	Body	Front Seat Heating Control Module																																																													
J	2014	Cruze	Body	Keyless Entry Control Module																																																													
J	2014	Cruze	Body	Right Side Object Detection Control Module																																																													
J	2014	Cruze	Body	Left Side Object Detection Control Module																																																													
J	2014	Cruze	Body	Parking Assist Control Module																																																													
J	2014	Cruze	Body	Steering Column Lock Control Module																																																													
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module																																																												
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2014	Sonic	Powertrain	1.4L LDD Chassis Control Module																																																												
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.4L LUJ Chassis Control Module																																																												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(B) 1.4L LUV Chassis Control Module																																																												
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(C) 1.6L LDE Chassis Control Module																																																												
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	1.6L LED Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(H) 1.8L LUW Chassis Control Module																																																												
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
J	2014	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2014	Sonic	Powertrain	(G) 1.8L LWE Chassis Control Module																																																												
J	2014	Sonic	Powertrain	Fuel Injector Control Module																																																												
J	2014	Sonic	Chassis	Electronic Brake Control Module																																																												
J	2014	Sonic	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2014	Sonic	Chassis	Power Steering Control Module																																																												
J	2014	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Sonic	Body	Body Control Module Hatchback																																																												
J	2014	Sonic	Body	Body Control Module Sedan																																																												
J	2014	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Sonic	Body	Passenger Presence Module																																																												
J	2014	Sonic	Body	Instrument Cluster																																																												
J	2014	Sonic	Body	Radio																																																											
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2014	Sonic	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Sonic	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Sonic	Body	Front Seat Heating Control Module																																																												
J	2014	Sonic	Body	Parking Assist Control Module																																																												
J	2014	Sonic	Body	Frontview Camera Module																																																												
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																												
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																												
J	2014	Spin	Powertrain	1.5L L2B Transmission Control Module																																																												
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Automatic Transmission																																																												
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Manual Transmission																																																												
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2014	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
J	2014	Spin	Powertrain	1.8L LMD Transmission Control Module																																																												
J	2014	Spin	Chassis	Electronic Brake Control Module																																																												
J	2014	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2014	Spin	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Spin	Body	Body Control Module																																																												
J	2014	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Spin	Body	Instrument Cluster																																																												
J	2014	Spin	Body	Radio																																																												
J	2014	Spin	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Spin	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Spin	Body	Parking Assist Control Module																																																												
J	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																												
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
J	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																												
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																												
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
J	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																											
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
J	2015	Aveo	Powertrain	Chassis Control Module																																																												
J	2015	Aveo	Powertrain	Fuel Injector Control Module																																																												
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2015	Aveo	Chassis	Power Steering Control Module																																																												
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2015	Aveo	Body	Body Control Module Hatchback																																																												
J	2015	Aveo	Body	Body Control Module Sedan																																																												
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2015	Aveo	Body	Instrument Cluster																																																											
J	2015	Aveo	Body	Radio																																																										
J	2015	Aveo	Body	Telematics Communication Interface Control Module																																																											
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
J	2015	Aveo	Body	Front Seat Heating Control Module																																																											
J	2015	Aveo	Body	Keyless Entry Control Module																																																											
J	2015	Aveo	Body	Parking Assist Control Module																																																											
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																											
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																											
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																											
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																											
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																											
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																											
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																											
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																											
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																											
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																											
J	2015	Cobalt	Chassis	Electronic Brake Control Module																																																											
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2015	Cobalt	Body	Body Control Module																																																											
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2015	Cobalt	Body	Instrument Cluster																																																											
J	2015	Cobalt	Body	Radio																																																										
J	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																											
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Cobalt	Body	Front Seat Heating Control Module																																																										
J	2015	Cobalt	Body	Parking Assist Control Module																																																										
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																										
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																											
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																											
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																											
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																											
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																											
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
J	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																												
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																												
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																												
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																												
J	2015	Cruze	Powertrain	Fuel Injector Control Module																																																												
J	2015	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2015	Cruze	Chassis	Power Steering Control Module																																																												
J	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2015	Cruze	Body	Body Control Module Hatchback																																																												
J	2015	Cruze	Body	Body Control Module Sedan																																																												
J	2015	Cruze	Body	Body Control Module Station Wagon																																																												
J	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2015	Cruze	Body	Passenger Presence Module																																																												
J	2015	Cruze	Body	Instrument Cluster																																																												
J	2015	Cruze	Body	Trailer Interface Control Module																																																												
J	2015	Cruze	Body	Radio																																																												
J	2015	Cruze	Body	Digital Radio Receiver Control Module																																																												
J	2015	Cruze	Body	Multimedia Player Interface Module																																																												
J	2015	Cruze	Body	Mobile Telephone Control Module																																																												
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																												
J	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																												
J	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																												
J	2015	Cruze	Body	Front Seat Heating Control Module																																																												
J	2015	Cruze	Body	Keyless Entry Control Module																																																												
J	2015	Cruze	Body	Right Side Object Detection Control Module																																																												
J	2015	Cruze	Body	Left Side Object Detection Control Module																																																												
J	2015	Cruze	Body	Parking Assist Control Module																																																												
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2015	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																											
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	1.6L LED Transmission Control Module																																																												
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
J	2015	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2015	Sonic	Powertrain	Chassis Control Module																																																												
J	2015	Sonic	Powertrain	Fuel Injector Control Module																																																												
J	2015	Sonic	Chassis	Electronic Brake Control Module																																																												
J	2015	Sonic	Chassis	Power Steering Control Module																																																												
J	2015	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2015	Sonic	Body	Body Control Module Hatchback																																																												
J	2015	Sonic	Body	Body Control Module Sedan																																																												
J	2015	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2015	Sonic	Body	Passenger Presence Module																																																												
J	2015	Sonic	Body	Instrument Cluster																																																												
J	2015	Sonic	Body	Radio																																																											
J	2015	Sonic	Body	Telematics Communication Interface Control Module																																																												
J	2015	Sonic	Body	HVAC Control Module Heater Only (C41)																																																												
J	2015	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2015	Sonic	Body	HVAC Control Module Single Zone (C60)																																																												
J	2015	Sonic	Body	Front Seat Heating Control Module																																																												
J	2015	Sonic	Body	Parking Assist Control Module																																																												
J	2015	Sonic	Body	Frontview Camera Module																																																												
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																												
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																												
J	2015	Spin	Powertrain	1.5L L2B Transmission Control Module																																																												
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																											
J	2015	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
J	2015	Spin	Powertrain	1.8L LMD Transmission Control Module																																																												
J	2015	Spin	Chassis	Electronic Brake Control Module																																																												
J	2015	Spin	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2015	Spin	Body	Body Control Module																																																												
J	2015	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2015	Spin	Body	Instrument Cluster																																																												
J	2015	Spin	Body	Radio																																																												
J	2015	Spin	Body	Telematics Communication Interface Control Module																																																												
J	2015	Spin	Body	HVAC Control Module Heater Only (C41)																																																												
J	2015	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2015	Spin	Body	HVAC Control Module Single Zone (C60)																																																												
J	2015	Spin	Body	Front Seat Heating Control Module																																																												
J	2015	Spin	Body	Parking Assist Control Module																																																												
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																												
J	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
J	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																												
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
J	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
J	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
J	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2016	Aveo	Powertrain	Chassis Control Module																																																												
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																												
J	2016	Aveo	Chassis	Power Steering Control Module																																																												
J	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Aveo	Body	Body Control Module Hatchback																																																												
J	2016	Aveo	Body	Body Control Module Sedan																																																												
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Aveo	Body	Instrument Cluster																																																												
J	2016	Aveo	Body	Radio																																																												
J	2016	Aveo	Body	Telematics Communication Interface Control Module																																																												
J	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
J	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
J	2016	Aveo	Body	Front Seat Heating Control Module																																																												
J	2016	Aveo	Body	Parking Assist Control Module																																																												
J	2016	Aveo	Body	Keyless Entry Control Module																																																												
J	2016	Aveo	Body	Frontview Camera Module																																																												
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																												
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																												
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																												
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																												
J	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																												
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																												
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																												
J	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																												
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																												
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																												
J	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																												
J	2016	Cobalt	Chassis	Electronic Brake Control Module																																																												
J	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Cobalt	Body	Body Control Module																																																												
J	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Cobalt	Body	Instrument Cluster																																																												
J	2016	Cobalt	Body	Radio Other																																																												
J	2016	Cobalt	Body	Radio (IOB)																																																												
J	2016	Cobalt	Body	Radio (UF7)																																																												
J	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																												
J	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																												
J	2016	Cobalt	Body	Front Seat Heating Control Module																																																												
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
J	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																												
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
J	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
J	2016	Cruze	Powertrain	Fuel Injector Control Module																																																												
J	2016	Cruze	Powertrain	Chassis Control Module																																																												
J	2016	Cruze	Chassis	Electronic Brake Control Module																																																												
J	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2016	Cruze	Chassis	Power Steering Control Module																																																												
J	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Cruze	Body	Body Control Module Hatchback																																																												
J	2016	Cruze	Body	Body Control Module Sedan																																																												
J	2016	Cruze	Body	Body Control Module Station Wagon																																																												
J	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Cruze	Body	Passenger Presence Module																																																												
J	2016	Cruze	Body	Instrument Cluster																																																												
J	2016	Cruze	Body	Trailer Interface Control Module																																																												
J	2016	Cruze	Body	Radio Other																																																											
J	2016	Cruze	Body	Radio (UF7)																																																											
J	2016	Cruze	Body	Multimedia Player Interface Module																																																											
J	2016	Cruze	Body	Mobile Telephone Control Module																																																											
J	2016	Cruze	Body	Telematics Communication Interface Control Module																																																											
J	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
J	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																											
J	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																											
J	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																											
J	2016	Cruze	Body	Front Seat Heating Control Module																																																											
J	2016	Cruze	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2016	Cruze	Body	Right Side Object Detection Control Module																																																											
J	2016	Cruze	Body	Left Side Object Detection Control Module																																																												
J	2016	Cruze	Body	Parking Assist Control Module																																																												
J	2016	Cruze	Body	Steering Column Lock Control Module																																																												
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																												
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																												
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module																																																												
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
J	2016	Sonic	Powertrain	Chassis Control Module																																																												
J	2016	Sonic	Powertrain	Fuel Injector Control Module																																																												
J	2016	Sonic	Chassis	Electronic Brake Control Module																																																												
J	2016	Sonic	Chassis	Power Steering Control Module																																																												
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Sonic	Body	Body Control Module Hatchback																																																												
J	2016	Sonic	Body	Body Control Module Sedan																																																												
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Sonic	Body	Passenger Presence Module																																																												
J	2016	Sonic	Body	Instrument Cluster																																																												
J	2016	Sonic	Body	Radio Other																																																											
J	2016	Sonic	Body	Radio (UF7)																																																											
J	2016	Sonic	Body	Radio (UH7)																																																											
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7																																																											
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)																																																									
J	2016	Sonic	Body	Front Seat Heating Control Module																																																										
J	2016	Sonic	Body	Parking Assist Control Module																																																										
J	2016	Sonic	Body	Frontview Camera Module																																																										
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module																																																										
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2016	Spin	Chassis	Electronic Brake Control Module																																																										
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Spin	Body	Body Control Module																																																										
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Spin	Body	Instrument Cluster																																																										
J	2016	Spin	Body	Radio																																																										
J	2016	Spin	Body	Telematics Communication Interface Control Module																																																										
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Spin	Body	Front Seat Heating Control Module																																																										
J	2016	Spin	Body	Parking Assist Control Module																																																										
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																										
K	2006	ALL	Powertrain	Transmission Control Module																																																										
K	2006	ALL	Chassis	Electronic Brake Control Module																																																										
K	2006	ALL	Body	Remote Function Actuation																																																										
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																										
K	2007	ALL	Powertrain	Transmission Control Module																																																										
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module																																																										
K	2007	ALL	Chassis	Teves Electronic Brake Control Module																																																										
K	2007	ALL	Body	Remote Function Actuation																																																										
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																										
K	2008	ALL	Powertrain	Transmission Control Module																																																										
K	2008	ALL	Chassis	Electronic Brake Control Module																																																										
K	2008	ALL	Body	Remote Function Actuation																																																										
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
K	2009	ALL	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2009	ALL	Chassis	Electronic Brake Control Module																																																											
K	2009	ALL	Body	Remote Function Actuation																																																												
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2010	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2010	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2010	ALL	Powertrain	Transmission Control Module																																																												
K	2010	ALL	Chassis	Electronic Brake Control Module																																																												
K	2010	ALL	Body	Remote Function Actuation																																																												
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2011	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2011	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2011	ALL	Powertrain	Transmission Control Module																																																												
K	2011	ALL	Chassis	Electronic Brake Control Module																																																												
K	2011	ALL	Body	Remote Function Actuation																																																												
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2012	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2012	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2012	ALL	Powertrain	Transmission Control Module																																																												
K	2012	ALL	Chassis	Electronic Brake Control Module																																																												
K	2012	ALL	Body	Remote Function Actuation																																																												
K	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2013	Onix	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																												
K	2013	Onix	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																												
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																												
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																												
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																												
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																												
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																												
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																												
K	2013	Onix	Powertrain	Transmission Control Module																																																												
K	2013	Onix	Powertrain	Transmission Control Module																																																												
K	2013	Onix	Chassis	Electronic Brake Control Module																																																												
K	2013	Onix	Chassis	Electronic Brake Control Module																																																												
K	2013	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2013	Onix	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2013	Onix	Body	Body Control Module																																																												
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2013	Onix	Body	Instrument Cluster																																																												
K	2013	Onix	Body	Radio																																																												
K	2013	Onix	Body	Parking Assist Control Module																																																												
K	2013	Onix	Body	Remote Function Actuation																																																												
K	2013	Prisma	Powertrain	Engine Control Module																																																												
K	2013	Prisma	Powertrain	Transmission Control Module																																																												
K	2013	Prisma	Chassis	Electronic Brake Control Module																																																												
K	2013	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2013	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2013	Prisma	Body	Body Control Module																																																												
K	2013	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2013	Prisma	Body	Instrument Cluster																																																												
K	2013	Prisma	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2013	Prisma	Body	Parking Assist Control Module																																																										
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2014	Onix	Chassis	Electronic Brake Control Module																																																										
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Onix	Body	Body Control Module																																																										
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Onix	Body	Instrument Cluster																																																										
K	2014	Onix	Body	Radio																																																										
K	2014	Onix	Body	Parking Assist Control Module																																																										
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module																																																										
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2014	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Prisma	Body	Body Control Module																																																										
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Prisma	Body	Instrument Cluster																																																										
K	2014	Prisma	Body	Radio																																																										
K	2014	Prisma	Body	Parking Assist Control Module																																																										
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2015	Onix	Chassis	Electronic Brake Control Module																																																										
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Onix	Body	Body Control Module																																																										
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Onix	Body	Instrument Cluster																																																										
K	2015	Onix	Body	Radio																																																										
K	2015	Onix	Body	Parking Assist Control Module																																																										
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2015	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2015	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2015	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Prisma	Body	Body Control Module																																																										
K	2015	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Prisma	Body	Instrument Cluster																																																										
K	2015	Prisma	Body	Radio																																																										
K	2015	Prisma	Body	Parking Assist Control Module																																																										
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2016	Onix	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2016	Onix	Chassis	Electronic Brake Control Module																																																										
K	2016	Onix	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Onix	Body	Body Control Module																																																										
K	2016	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Onix	Body	Instrument Cluster																																																										
K	2016	Onix	Body	Radio																																																										
K	2016	Onix	Body	Parking Assist Control Module																																																										
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																										
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																										
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																										
K	2016	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																										
K	2016	Prisma	Chassis	Electronic Brake Control Module																																																										
K	2016	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Prisma	Body	Body Control Module																																																										
K	2016	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Prisma	Body	Instrument Cluster																																																										
K	2016	Prisma	Body	Radio																																																										
K	2016	Prisma	Body	HVAC Control Module																																																										
K	2016	Prisma	Body	Front Seat Heating Control Module																																																										
K	2016	Prisma	Body	Parking Assist Control Module																																																										
L	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
L	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module												V	V	V	V																																											
L	2004	ALL	Powertrain	Transmission Control Module																																																										
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																V																																								
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																									
L	2004	ALL	Body	Supplemental Inflatable Restraint																	V	V																																							

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2004	ALL	Body	ISU																			V	V																																						
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module												V	V	V	V																																											
L	2005	ALL	Powertrain	Transmission Control Module																																																											
L	2005	ALL	Chassis	Anti-lock Brake System																																																											
L	2005	ALL	Body	Supplemental Inflatable Restraint																	V	V																																								
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2005	ALL	Body	ISU																			V	V																																						
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																					V	V																																					
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																											
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																											
L	2006	ALL	Body	Supplemental Inflatable Restraint																	V	V																																								
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2006	ALL	Body	ISU																			V	V																																						
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																					V	V																																					
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																							V																																				
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																					V	V																																					
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																					V	V																																					
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector																																																											
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
L	2007	ALL	Chassis	Electronic Brake Control Module																																																											
L	2007	ALL	Body	Supplemental Inflatable Restraint																	V	V																																								
L	2007	ALL	Body	ISU																			V	V																																						
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																						V		V	V	V																																	
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																							V																																				
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																						V		V	V	V																																	
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
L	2008	ALL	Chassis	Electronic Brake Control Module																																																											
L	2008	ALL	Body	Supplemental Inflatable Restraint																	V	V																																								
L	2008	ALL	Body	ISU																			V	V																																						
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																						V		V	V	V																																	
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																							V																																				
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																						V		V	V	V																																	
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed																											V	V																														
L	2009	ALL	Chassis	Electronic Brake Control Module																																																											
L	2009	ALL	Body	Supplemental Inflatable Restraint																	V	V																																								
L	2009	ALL	Body	ISU																			V	V																																						
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																						V		V	V	V																																	
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																						V		V	V	V																																	
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																							V																																				
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																											
L	2010	ALL	Chassis	Electronic Brake Control Module																																																											
L	2010	ALL	Body	Supplemental Inflatable Restraint																	V	V																																								
L	2010	ALL	Body	ISU																			V	V																																						
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																						V		V	V	V																																	
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																						V		V	V	V																																	

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																							V																																			
L	2011	ALL	Powertrain	Transmission Control Module 6 Speed																											V	V																														
L	2011	ALL	Chassis	Electronic Brake Control Module																																																										
L	2011	ALL	Body	Supplemental Inflatable Restraint																	V	V																																								
L	2011	ALL	Body	ISU																			V	V																																						
M	2004	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2004	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2004	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2004	ALL	Chassis	Anti-lock Brake System																																																										
M	2004	ALL	Body	Remote Function Actuation																																																										
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2005	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2005	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2005	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2005	ALL	Chassis	Anti-lock Brake System																																																										
M	2005	ALL	Body	Remote Function Actuation																																																										
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2006	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2006	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2006	ALL	Chassis	Anti-lock Brake System																																																										
M	2006	ALL	Body	Remote Function Actuation																																																										
M	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2007	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2007	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2007	ALL	Chassis	Anti-lock Brake System																																																										
M	2007	ALL	Body	Remote Function Actuation																																																										
M	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2008	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2008	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2008	ALL	Chassis	Anti-lock Brake System																																																										
M	2008	ALL	Body	Remote Function Actuation																																																										
M	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2009	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2009	ALL	Chassis	Anti-lock Brake System																																																										
M	2009	ALL	Body	Remote Function Actuation																																																										
M	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
M	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
M	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
M	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2010	Spark	Powertrain	Transmission Control Module																																																										
M	2010	Spark	Chassis	Electronic Brake Control Module																																																										
M	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2010	Spark	Chassis	Electric Power Steering Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
M	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2010	Spark	Body	Passenger Presence Module																																																										
M	2010	Spark	Body	Instrument Cluster																																																										
M	2011	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																													V	V	V	V																										
M	2011	Caprice	Powertrain	Transmission Control Module																																																										
M	2011	Caprice	Powertrain	Fuel Pump Control Module																																																										
M	2011	Caprice	Chassis	Electronic Brake Control Module																																V																										
M	2011	Caprice	Body	Body Control Module																																																										
M	2011	Caprice	Body	HVAC Control Module																																																										
M	2011	Caprice	Body	Instrument Panel Cluster																																	V	V	V	V																						
M	2011	Caprice	Body	Passenger Presence System																																																										
M	2011	Caprice	Body	Radio																																																										
M	2011	Caprice	Body	Remote Control Door Lock Receiver																																																										
M	2011	Caprice	Body	Supplemental Inflatable Restraint																																																										
M	2011	Caprice	Body	Theft Deterrent Module																																					V	V																				
M	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
M	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
M	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
M	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										
M	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
M	2011	Spark	Powertrain	Transmission Control Module																																																										
M	2011	Spark	Chassis	Electronic Brake Control Module																																																										
M	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2011	Spark	Chassis	Electric Power Steering Control Module																																																										
M	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2011	Spark	Body	Passenger Presence Module																																																										
M	2011	Spark	Body	Instrument Cluster																																																										
M	2012	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
M	2012	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																													V	V	V	V																										
M	2012	Caprice	Powertrain	Transmission Control Module																																																										
M	2012	Caprice	Powertrain	Fuel Pump Control Module																																																										
M	2012	Caprice	Chassis	Electronic Brake Control Module																																V																										
M	2012	Caprice	Body	Body Control Module																																																										
M	2012	Caprice	Body	HVAC Control Module																																																										
M	2012	Caprice	Body	Instrument Panel Cluster																																	V	V	V	V																						
M	2012	Caprice	Body	Passenger Presence System																																																										
M	2012	Caprice	Body	Radio																																																										
M	2012	Caprice	Body	Remote Control Door Lock Receiver																																																										
M	2012	Caprice	Body	Supplemental Inflatable Restraint																																																										
M	2012	Caprice	Body	Theft Deterrent Module																																					V	V																				
M	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
M	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
M	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
M	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																										
M	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
M	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
M	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																										
M	2012	Spark	Powertrain	Transmission Control Module																																																										
M	2012	Spark	Chassis	Electronic Brake Control Module																																																										
M	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2012	Spark	Chassis	Electric Power Steering Control Module																																																										
M	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2012	Spark	Body	Passenger Presence Module																																																										
M	2012	Spark	Body	Instrument Cluster																																																										
M	2013	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
M	2013	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																													V	V	V	V																										
M	2013	Caprice	Powertrain	Transmission Control Module																																																										
M	2013	Caprice	Powertrain	Fuel Pump Control Module																																																										
M	2013	Caprice	Chassis	Electronic Brake Control Module																																	V																									
M	2013	Caprice	Body	Body Control Module																																																										
M	2013	Caprice	Body	HVAC Control Module																																																										
M	2013	Caprice	Body	Instrument Panel Cluster																																		V	V	V	V																					
M	2013	Caprice	Body	Passenger Presence System																																																										
M	2013	Caprice	Body	Radio																																																										
M	2013	Caprice	Body	Remote Control Door Lock Receiver																																																										
M	2013	Caprice	Body	Supplemental Inflatable Restraint																																																										
M	2013	Caprice	Body	Theft Deterrent Module																																						V	V																			
M	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																										
M	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																										
M	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																										
M	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2013	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2013	Spark	Chassis	Electronic Brake Control Module																																																										
M	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2013	Spark	Chassis	Power Steering Control Module																																																										
M	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2013	Spark	Body	Body Control Module																																																										
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2013	Spark	Body	Passenger Presence Module																																																										
M	2013	Spark	Body	Instrument Cluster																																																										
M	2013	Spark	Body	Radio																																																										
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
M	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
M	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
M	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
M	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																											
M	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
M	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																											
M	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																											
M	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
M	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
M	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
M	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
M	2014	Spark	Powertrain	Fuel Injector Control Module																																																											
M	2014	Spark	Chassis	Electronic Brake Control Module																																																											
M	2014	Spark	Chassis	Electronic Brake Control Module																																																											
M	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
M	2014	Spark	Chassis	Power Steering Control Module																																																											
M	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
M	2014	Spark	Body	Body Control Module																																																											
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2014	Spark	Body	Passenger Presence Module																																																											
M	2014	Spark	Body	Instrument Cluster																																																											
M	2014	Spark	Body	Radio																																																											
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
M	2014	Spark	Body	Keyless Entry Control Module																																																											
M	2014	Spark EV	Powertrain	Engine Control Module																																																											
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
M	2014	Spark EV	Powertrain	Drive Motor Control Module																																																											
M	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											
M	2014	Spark EV	Chassis	Electronic Brake Control Module																																																											
M	2014	Spark EV	Chassis	Parking Brake Control Module																																																											
M	2014	Spark EV	Chassis	Power Steering Control Module																																																											
M	2014	Spark EV	Body	Body Control Module																																																											
M	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
M	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2014	Spark EV	Body	Passenger Presence Module																																																											
M	2014	Spark EV	Body	Instrument Cluster																																																											
M	2014	Spark EV	Body	Radio																																																											
M	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																											
M	2014	Spark EV	Body	HVAC Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
M	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2014	Spark EV	Body	Coolant Heater Control Module																																																											
M	2014	Spark EV	Body	Keyless Entry Control Module																																																											
M	2014	Spark EV	Body	Battery Charger Control Module																																																											
M	2014	Spark EV	Body	DC Charging Control Module																																																											
M	2014	Spark EV	Body	Battery Energy Control Module																																																											
M	2015	Matiz	Powertrain	1.0L LA2 Engine Control Module																																																											
M	2015	Matiz	Chassis	Electronic Brake Control Module																																																											
M	2015	Matiz	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Matiz	Body	Keyless Entry Control Module																																																											
M	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																											
M	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																											
M	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																											
M	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																											
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																											
M	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																											
M	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																											
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																											
M	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																											
M	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																											
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																											
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																											
M	2015	Spark	Powertrain	Fuel Injector Control Module																																																											
M	2015	Spark	Chassis	Electronic Brake Control Module																																																											
M	2015	Spark	Chassis	Electronic Brake Control Module																																																											
M	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																											
M	2015	Spark	Chassis	Power Steering Control Module																																																											
M	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																											
M	2015	Spark	Body	Body Control Module																																																											
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Spark	Body	Passenger Presence Module																																																											
M	2015	Spark	Body	Instrument Cluster																																																											
M	2015	Spark	Body	Instrument Cluster																																																											
M	2015	Spark	Body	Tire Pressure Indicator Module																																																											
M	2015	Spark	Body	Radio																																																											
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																											
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																											
M	2015	Spark	Body	Keyless Entry Control Module																																																											
M	2015	Spark EV	Powertrain	Engine Control Module																																																											
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																											
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																											
M	2015	Spark EV	Powertrain	Drive Motor Control Module																																																											
M	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
M	2015	Spark EV	Chassis	Electronic Brake Control Module																																																											
M	2015	Spark EV	Chassis	Parking Brake Control Module																																																											
M	2015	Spark EV	Chassis	Power Steering Control Module																																																											
M	2015	Spark EV	Body	Body Control Module																																																											
M	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																											
M	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	Spark EV	Body	Passenger Presence Module																																																											
M	2015	Spark EV	Body	Instrument Cluster																																																											
M	2015	Spark EV	Body	Radio																																																										
M	2015	Spark EV	Body	HVAC Control Module																																																										
M	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																										
M	2015	Spark EV	Body	Coolant Heater Control Module																																																										
M	2015	Spark EV	Body	Keyless Entry Control Module																																																										
M	2015	Spark EV	Body	Battery Charger Control Module																																																										
M	2015	Spark EV	Body	DC Charging Control Module																																																										
M	2015	Spark EV	Body	Battery Energy Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
M	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																										
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
M	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2016	Spark	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark	Chassis	Electronic Brake Control Module																																																										
M	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2016	Spark	Chassis	Power Steering Control Module																																																										
M	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2016	Spark	Body	Body Control Module																																																										
M	2016	Spark	Body	Body Control Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	Spark	Body	Instrument Cluster																																																										
M	2016	Spark	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
M	2016	Spark	Body	Radio																																																									
M	2016	Spark	Body	Telematics Communication Interface Control Module																																																									
M	2016	Spark	Body	Keyless Entry Control Module																																																									
M	2016	Spark EV	Powertrain	Engine Control Module																																																									
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																									
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																									
M	2016	Spark EV	Powertrain	Drive Motor Control Module																																																									
M	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																									
M	2016	Spark EV	Chassis	Electronic Brake Control Module																																																									
M	2016	Spark EV	Chassis	Parking Brake Control Module																																																									
M	2016	Spark EV	Chassis	Power Steering Control Module																																																									
M	2016	Spark EV	Body	Body Control Module																																																									
M	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																									
M	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2016	Spark EV	Body	Passenger Presence Module																																																									
M	2016	Spark EV	Body	Instrument Cluster																																																									
M	2016	Spark EV	Body	Radio																																																									
M	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																									
M	2016	Spark EV	Body	HVAC Control Module																																																									
M	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																									
M	2016	Spark EV	Body	Coolant Heater Control Module																																																									
M	2016	Spark EV	Body	Keyless Entry Control Module																																																									
M	2016	Spark EV	Body	Frontview Camera Module																																																									
M	2016	Spark EV	Body	Battery Charger Control Module																																																									
M	2016	Spark EV	Body	DC Charging Control Module																																																									
M	2016	Spark EV	Body	Battery Energy Control Module																																																									
N	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																									
N	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																									
N	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																									
N	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
N	2004	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
N	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																									
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																									
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																									
N	2004	Optra	Body	Remote Function Actuation																																																									
N	2004	Optra	Body	Supplemental Inflatable Restraint																																																									
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																									
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																									
N	2004	Classic	Chassis	Anti-lock Brake System																																																									
N	2004	Classic	Body	Body Control Module																																																									
N	2004	Classic	Body	Radio																																																									
N	2004	Classic	Body	Remote Function Actuation																																																									
N	2004	Classic	Body	Supplemental Inflatable Restraint																																																									
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																									
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Transmission Control Module																																																									
N	2004	Alero (Export)	Chassis	Anti-lock Brake System																																																									
N	2004	Alero (Export)	Body	Body Control Module																																																									
N	2004	Alero (Export)	Body	Instrument Panel Cluster																																																									
N	2004	Alero (Export)	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
N	2004	Alero (Export)	Body	Supplemental Inflatable Restraint																																																										
N	2004	Alero (Export)	Body	Vehicle Theft Deterrent																																																										
N	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
N	2005	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2005	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																										
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																										
N	2005	Optra	Body	Remote Function Actuation																																																										
N	2005	Optra	Body	Supplemental Inflatable Restraint																																																										
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
N	2005	Classic	Chassis	Anti-lock Brake System																																																										
N	2005	Classic	Body	Body Control Module																																																										
N	2005	Classic	Body	Radio																																																										
N	2005	Classic	Body	Remote Function Actuation																																																										
N	2005	Classic	Body	Supplemental Inflatable Restraint																																																										
N	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																										
N	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																										
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																										
N	2006	ALL	Body	Remote Function Actuation																																																										
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
N	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
N	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
N	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																										
N	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																										
N	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																										
N	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
N	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																										
N	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																										
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																										
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																										
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																										
N	2007	ALL	Chassis	Tire Pressure Monitor																																																										
N	2007	ALL	Body	Remote Function Actuation																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
N	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
N	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
N	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																												
N	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
N	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
N	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																												
N	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																																																												
N	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
N	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																												
N	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
N	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
N	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																												
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																												
N	2008	ALL	Chassis	Tire Pressure Monitor																																																												
N	2008	ALL	Body	Remote Function Actuation																																																												
N	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
N	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																												
N	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																												
N	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
N	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																												
N	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																												
N	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
N	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																												
N	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
N	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
N	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																												
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																												
N	2009	ALL	Chassis	Tire Pressure Monitor																																																												
N	2009	ALL	Body	Remote Function Actuation																																																												
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2010	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
N	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																												
N	2010	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																												
N	2010	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																												
N	2010	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																												
N	2010	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
N	2010	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																												
N	2010	ALL	Powertrain	Transmission Control Module 5 Speed																																																												
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																												
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																												
N	2010	ALL	Chassis	Tire Pressure Monitor																																																												
N	2010	ALL	Body	Remote Function Actuation																																																												
N	2010	ALL	Body	Remote Function Actuation																																																												
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
N	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
N	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
N	2011	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
N	2011	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																											
N	2011	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
N	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
N	2011	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
N	2011	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
N	2011	ALL	Chassis	Tire Pressure Monitor																																																											
N	2011	ALL	Body	Remote Function Actuation																																																											
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2012	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
N	2012	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
N	2012	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
N	2012	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																											
N	2012	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
N	2012	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
N	2012	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
N	2012	ALL	Chassis	Tire Pressure Monitor																																																											
N	2012	ALL	Body	Remote Function Actuation																																																											
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2013	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
N	2013	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
N	2013	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																											
N	2013	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																											
N	2013	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
N	2013	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
N	2013	ALL	Powertrain	Transmission Control Module 5 Speed																																																											
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																											
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																											
N	2013	ALL	Chassis	Tire Pressure Monitor																																																											
N	2013	ALL	Body	Remote Function Actuation																																																											
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
N	2014	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																											
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																											
N	2014	Caprice	Powertrain	(2) 6.0L L77 Chassis Control Module																																																											
N	2014	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																											
N	2014	Caprice	Chassis	Electronic Brake Control Module																																																											
N	2014	Caprice	Chassis	Parking Brake Control Module																																																											
N	2014	Caprice	Chassis	Power Steering Control Module																																																											
N	2014	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2014	Caprice	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
N	2014	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2014	Caprice	Body	Passenger Presence Module																																																												
N	2014	Caprice	Body	Instrument Cluster																																																												
N	2014	Caprice	Body	Radio Controls																																																											
N	2014	Caprice	Body	HVAC Controls																																																											
N	2014	Caprice	Body	Headlamp Control Module																																																											
N	2014	Caprice	Body	Trailer Interface Control Module																																																											
N	2014	Caprice	Body	Radio																																																											
N	2014	Caprice	Body	HVAC Control Module																																																											
N	2014	Caprice	Body	Parking Assist Control Module																																																											
N	2014	Caprice	Body	Frontview Camera Module																																																											
N	2014	Caprice	Body	Steering Column Lock Control Module																																																											
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
N	2015	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																											
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																											
N	2015	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																											
N	2015	Caprice	Powertrain	Fuel Injector Control Module																																																											
N	2015	Caprice	Chassis	Electronic Brake Control Module																																																											
N	2015	Caprice	Chassis	Parking Brake Control Module																																																											
N	2015	Caprice	Chassis	Power Steering Control Module																																																											
N	2015	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2015	Caprice	Chassis	Suspension Control Module																																																											
N	2015	Caprice	Body	Body Control Module																																																											
N	2015	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2015	Caprice	Body	Passenger Presence Module																																																											
N	2015	Caprice	Body	Instrument Cluster																																																											
N	2015	Caprice	Body	Head-Up Display Module																																																											
N	2015	Caprice	Body	Radio Controls																																																											
N	2015	Caprice	Body	HVAC Controls																																																											
N	2015	Caprice	Body	Headlamp Control Module																																																											
N	2015	Caprice	Body	Trailer Interface Control Module																																																											
N	2015	Caprice	Body	Radio																																																											
N	2015	Caprice	Body	Telematics Communication Interface Control Module																																																											
N	2015	Caprice	Body	HVAC Control Module																																																											
N	2015	Caprice	Body	Right Side Object Detection Control Module																																																											
N	2015	Caprice	Body	Left Side Object Detection Control Module																																																											
N	2015	Caprice	Body	Parking Assist Control Module																																																											
N	2015	Caprice	Body	Frontview Camera Module																																																											
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
N	2016	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																											
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																											
N	2016	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																											
N	2016	Caprice	Powertrain	Fuel Injector Control Module																																																											
N	2016	Caprice	Chassis	Electronic Brake Control Module																																																											
N	2016	Caprice	Chassis	Parking Brake Control Module																																																											
N	2016	Caprice	Chassis	Power Steering Control Module																																																											
N	2016	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
N	2016	Caprice	Chassis	Suspension Control Module																																																											
N	2016	Caprice	Body	Body Control Module																																																											
N	2016	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2016	Caprice	Body	Passenger Presence Module																																																											
N	2016	Caprice	Body	Instrument Cluster																																																											
N	2016	Caprice	Body	Head-Up Display Module																																																											
N	2016	Caprice	Body	Radio Controls																																																											
N	2016	Caprice	Body	HVAC Controls																																																											
N	2016	Caprice	Body	Trailer Interface Control Module																																																											
N	2016	Caprice	Body	Radio																																																											
N	2016	Caprice	Body	Telematics Communication Interface Control Module																																																											
N	2016	Caprice	Body	HVAC Control Module																																																											
N	2016	Caprice	Body	Seat Memory Control Module - Driver																																																											
N	2016	Caprice	Body	Right Side Object Detection Control Module																																																											
N	2016	Caprice	Body	Left Side Object Detection Control Module																																																											
N	2016	Caprice	Body	Parking Assist Control Module																																																											
N	2016	Caprice	Body	Frontview Camera Module																																																											
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																											
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																											
P	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																											
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																											
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																											
P	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																											
P	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																											
P	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																											
P	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																											
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																											
P	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																											
P	2010	Cruze	Chassis	Electronic Brake Control Module																																																											
P	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2010	Cruze	Body	Body Control Module																																																											
P	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2010	Cruze	Body	Passenger Presence Module																																																											
P	2010	Cruze	Body	Instrument Cluster																																																											
P	2010	Cruze	Body	Trailer Interface Control Module																																																											
P	2010	Cruze	Body	Radio																																																											
P	2010	Cruze	Body	Multimedia Player Interface Module																																																											
P	2010	Cruze	Body	Mobile Telephone Control Module																																																											
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2010	Cruze	Body	Keyless Entry Control Module																																																											
P	2010	Cruze	Body	Parking Assist Control Module																																																											
P	2010	Cruze	Body	Steering Column Lock Control Module																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																											
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																												
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																												
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																												
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																												
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																												
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																												
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																												
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																												
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																												
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																												
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																												
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																												
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2011	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2011	Cruze	Body	Body Control Module																																																												
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2011	Cruze	Body	Passenger Presence Module																																																												
P	2011	Cruze	Body	Instrument Cluster																																																												
P	2011	Cruze	Body	Trailer Interface Control Module																																																												
P	2011	Cruze	Body	Radio																																																											
P	2011	Cruze	Body	Multimedia Player Interface Module																																																											
P	2011	Cruze	Body	Mobile Telephone Control Module																																																											
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2011	Cruze	Body	Keyless Entry Control Module																																																											
P	2011	Cruze	Body	Parking Assist Control Module																																																											
P	2011	Cruze	Body	Steering Column Lock Control Module																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																											
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																											
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																											
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
P	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																											
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																												
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																												
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																												
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																												
P	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																												
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																												
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																												
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																												
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																												
P	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
P	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																												
P	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																												
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																												
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																												
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																												
P	2012	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2012	Cruze	Body	Body Control Module Hatchback																																																												
P	2012	Cruze	Body	Body Control Module Sedan																																																												
P	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2012	Cruze	Body	Passenger Presence Module																																																												
P	2012	Cruze	Body	Instrument Cluster																																																												
P	2012	Cruze	Body	Trailer Interface Control Module																																																												
P	2012	Cruze	Body	Radio																																																											
P	2012	Cruze	Body	Multimedia Player Interface Module																																																											
P	2012	Cruze	Body	Mobile Telephone Control Module																																																											
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2012	Cruze	Body	Keyless Entry Control Module																																																											
P	2012	Cruze	Body	Parking Assist Control Module																																																											
P	2012	Cruze	Body	Steering Column Lock Control Module																																																											
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																												
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																												
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																												
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
P	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																												
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
P	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
P	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																												
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																												
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																												
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																												
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2013	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2013	Cruze	Body	Body Control Module Hatchback																																																												
P	2013	Cruze	Body	Body Control Module Sedan																																																												
P	2013	Cruze	Body	Body Control Module Station Wagon																																																												
P	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2013	Cruze	Body	Passenger Presence Module																																																												
P	2013	Cruze	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
P	2013	Cruze	Body	Trailer Interface Control Module																																																											
P	2013	Cruze	Body	Radio																																																											
P	2013	Cruze	Body	Digital Radio Receiver Control Module																																																											
P	2013	Cruze	Body	Multimedia Player Interface Module																																																											
P	2013	Cruze	Body	Mobile Telephone Control Module																																																											
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																										
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																										
P	2013	Cruze	Body	Front Seat Heating Control Module																																																										
P	2013	Cruze	Body	Keyless Entry Control Module																																																										
P	2013	Cruze	Body	Right Side Object Detection Control Module																																																										
P	2013	Cruze	Body	Left Side Object Detection Control Module																																																										
P	2013	Cruze	Body	Parking Assist Control Module																																																										
P	2013	Cruze	Body	Steering Column Lock Control Module																																																										
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																										
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																										
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																											
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																												
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																													
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
P	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																	
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																													
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																													
P	2014	Cruze	Powertrain	Fuel Injector Control Module																																																														
P	2014	Cruze	Chassis	Electronic Brake Control Module																																																														
P	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																														
P	2014	Cruze	Chassis	Power Steering Control Module																																																														
P	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																														
P	2014	Cruze	Body	Body Control Module Hatchback																																																														
P	2014	Cruze	Body	Body Control Module Sedan																																																														
P	2014	Cruze	Body	Body Control Module Station Wagon																																																														
P	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
P	2014	Cruze	Body	Passenger Presence Module																																																														
P	2014	Cruze	Body	Instrument Cluster																																																														
P	2014	Cruze	Body	Trailer Interface Control Module																																																														
P	2014	Cruze	Body	Radio																																																														
P	2014	Cruze	Body	Digital Radio Receiver Control Module																																																														
P	2014	Cruze	Body	Multimedia Player Interface Module																																																														
P	2014	Cruze	Body	Mobile Telephone Control Module																																																														
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																														
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																														
P	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																														
P	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																														
P	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																														
P	2014	Cruze	Body	Front Seat Heating Control Module																																																														
P	2014	Cruze	Body	Keyless Entry Control Module																																																														
P	2014	Cruze	Body	Right Side Object Detection Control Module																																																														
P	2014	Cruze	Body	Left Side Object Detection Control Module																																																														
P	2014	Cruze	Body	Parking Assist Control Module																																																														
P	2014	Cruze	Body	Steering Column Lock Control Module																																																														

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																												
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																												
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																												
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																											
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																											
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																											
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																												
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																												
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																													
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																												
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																												
P	2015	Cruze	Powertrain	Fuel Injector Control Module																																																													
P	2015	Cruze	Chassis	Electronic Brake Control Module																																																													
P	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																													
P	2015	Cruze	Chassis	Power Steering Control Module																																																													
P	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																													
P	2015	Cruze	Body	Body Control Module Hatchback																																																													
P	2015	Cruze	Body	Body Control Module Sedan																																																													
P	2015	Cruze	Body	Body Control Module Station Wagon																																																													
P	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
P	2015	Cruze	Body	Passenger Presence Module																																																													
P	2015	Cruze	Body	Instrument Cluster																																																													
P	2015	Cruze	Body	Trailer Interface Control Module																																																													
P	2015	Cruze	Body	Radio																																																													
P	2015	Cruze	Body	Digital Radio Receiver Control Module																																																													
P	2015	Cruze	Body	Multimedia Player Interface Module																																																													
P	2015	Cruze	Body	Mobile Telephone Control Module																																																													
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																													
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																													
P	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																													
P	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																													
P	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																													
P	2015	Cruze	Body	Front Seat Heating Control Module																																																													
P	2015	Cruze	Body	Keyless Entry Control Module																																																													
P	2015	Cruze	Body	Right Side Object Detection Control Module																																																													
P	2015	Cruze	Body	Left Side Object Detection Control Module																																																													
P	2015	Cruze	Body	Parking Assist Control Module																																																													
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
P	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																													
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
P	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																													
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																													
P	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																													
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																													
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																													
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																													

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																											
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																												
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2016	Cruze	Powertrain	Fuel Injector Control Module																																																												
P	2016	Cruze	Powertrain	Chassis Control Module																																																												
P	2016	Cruze	Chassis	Electronic Brake Control Module																																																												
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2016	Cruze	Chassis	Power Steering Control Module																																																												
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2016	Cruze	Body	Body Control Module Hatchback																																																												
P	2016	Cruze	Body	Body Control Module Sedan																																																												
P	2016	Cruze	Body	Body Control Module Station Wagon																																																												
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2016	Cruze	Body	Passenger Presence Module																																																												
P	2016	Cruze	Body	Instrument Cluster																																																												
P	2016	Cruze	Body	Trailer Interface Control Module																																																												
P	2016	Cruze	Body	Radio Other																																																												
P	2016	Cruze	Body	Radio (UF7)																																																												
P	2016	Cruze	Body	Multimedia Player Interface Module																																																												
P	2016	Cruze	Body	Mobile Telephone Control Module																																																												
P	2016	Cruze	Body	Telematics Communication Interface Control Module																																																												
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																												
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																												
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																												
P	2016	Cruze	Body	Front Seat Heating Control Module																																																												
P	2016	Cruze	Body	Keyless Entry Control Module																																																												
P	2016	Cruze	Body	Right Side Object Detection Control Module																																																												
P	2016	Cruze	Body	Left Side Object Detection Control Module																																																												
P	2016	Cruze	Body	Parking Assist Control Module																																																												
P	2016	Cruze	Body	Steering Column Lock Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2011	Volt	Powertrain	Engine Control Module																																																								
R	2011	Volt	Powertrain	Trasmission Control Module																																																									
R	2011	Volt	Powertrain	Fuel Pump Control Module																																																									
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module																																																									
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																									
R	2011	Volt	Powertrain	Drive Motor Control Module 1																																																									
R	2011	Volt	Powertrain	Drive Motor Control Module 2																																																									
R	2011	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																									
R	2011	Volt	Chassis	Electronic Brake Control Module																																																									
R	2011	Volt	Chassis	Parking Brake Control Module																																																									
R	2011	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																									
R	2011	Volt	Chassis	Power Steering Control Module																																																									
R	2011	Volt	Chassis	Steering Wheel Angle Sensor Module																																																									
R	2011	Volt	Body	Body Control Module																																																									
R	2011	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
R	2011	Volt	Body	Passenger Presence Module																																																									
R	2011	Volt	Body	Instrument Cluster																																										V															
R	2011	Volt	Body	Radio																																																									
R	2011	Volt	Body	Digital Radio Receiver Control Module																																																									
R	2011	Volt	Body	Mobile Telephone Control Module																																																									
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 9																																																									
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 10																																																									
R	2011	Volt	Body	Remote Heater and Air Conditioning Control Module																																																									
R	2011	Volt	Body	Electric A/C Compressor Control Module																																																									
R	2011	Volt	Body	Coolant Heater Control Module																																																									
R	2011	Volt	Body	Keyless Entry Control Module																																																									
R	2011	Volt	Body	Parking Assist Control Module																																																									
R	2011	Volt	Body	Steering Column Lock Control Module																																																									
R	2011	Volt	Body	Battery Charger Control Module																																																									
R	2011	Volt	Body	Battery Energy Control Module																																																									
R	2012	Volt	Powertrain	Engine Control Module																																																									
R	2012	Volt	Powertrain	Trasmission Control Module																																																									
R	2012	Volt	Powertrain	Fuel Pump Control Module																																																									
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module																																																									
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																									
R	2012	Volt	Powertrain	Drive Motor Control Module 1																																																									
R	2012	Volt	Powertrain	Drive Motor Control Module 2																																																									
R	2012	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																									
R	2012	Volt	Chassis	Electronic Brake Control Module																																																									
R	2012	Volt	Chassis	Parking Brake Control Module																																																									
R	2012	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																									
R	2012	Volt	Chassis	Power Steering Control Module																																																									
R	2012	Volt	Chassis	Steering Wheel Angle Sensor Module																																																									
R	2012	Volt	Body	Body Control Module																																																									
R	2012	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
R	2012	Volt	Body	Passenger Presence Module																																																									
R	2012	Volt	Body	Instrument Cluster																																										V															
R	2012	Volt	Body	Radio																																																									
R	2012	Volt	Body	Digital Radio Receiver Control Module																																																									
R	2012	Volt	Body	Mobile Telephone Control Module																																																									
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 9																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2012	Volt	Body	Remote Heater and Air Conditioning Control Module																																																											
R	2012	Volt	Body	Electric A/C Compressor Control Module																																																											
R	2012	Volt	Body	Coolant Heater Control Module																																																											
R	2012	Volt	Body	Keyless Entry Control Module																																																											
R	2012	Volt	Body	Parking Assist Control Module																																																											
R	2012	Volt	Body	Steering Column Lock Control Module																																																											
R	2012	Volt	Body	Battery Charger Control Module																																																											
R	2012	Volt	Body	Battery Energy Control Module																																																											
R	2013	Volt	Powertrain	Engine Control Module																																																											
R	2013	Volt	Powertrain	Trasmission Control Module																																																											
R	2013	Volt	Powertrain	Fuel Pump Control Module																																																											
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module																																																											
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2013	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2013	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2013	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2013	Volt	Chassis	Electronic Brake Control Module																																																											
R	2013	Volt	Chassis	Parking Brake Control Module																																																											
R	2013	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																											
R	2013	Volt	Chassis	Power Steering Control Module																																																											
R	2013	Volt	Chassis	Steering Wheel Angle Sensor Module																																																											
R	2013	Volt	Body	Body Control Module																																																											
R	2013	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2013	Volt	Body	Passenger Presence Module																																																											
R	2013	Volt	Body	Instrument Cluster																																																											
R	2013	Volt	Body	Radio																																																											
R	2013	Volt	Body	Digital Radio Receiver Control Module																																																											
R	2013	Volt	Body	Multimedia Player Interface Module																																																											
R	2013	Volt	Body	Mobile Telephone Control Module																																																											
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2013	Volt	Body	HVAC Control Module																																																											
R	2013	Volt	Body	Electric A/C Compressor Control Module																																																											
R	2013	Volt	Body	Coolant Heater Control Module																																																											
R	2013	Volt	Body	Front Seat Heating Control Module																																																											
R	2013	Volt	Body	Keyless Entry Control Module																																																											
R	2013	Volt	Body	Parking Assist Control Module																																																											
R	2013	Volt	Body	Frontview Camera Module																																																											
R	2013	Volt	Body	Steering Column Lock Control Module																																																											
R	2013	Volt	Body	Battery Charger Control Module																																																											
R	2013	Volt	Body	Battery Energy Control Module																																																											
R	2014	Volt	Powertrain	Engine Control Module																																																											
R	2014	Volt	Powertrain	Trasmission Control Module																																																											
R	2014	Volt	Powertrain	Chassis Control Module																																																											
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module																																																											
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																											
R	2014	Volt	Powertrain	Drive Motor Control Module 1																																																											
R	2014	Volt	Powertrain	Drive Motor Control Module 2																																																											
R	2014	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																											
R	2014	Volt	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2014	Volt	Chassis	Parking Brake Control Module																																																											
R	2014	Volt	Chassis	Power Steering Control Module																																																												
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2014	Volt	Body	Body Control Module																																																												
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Volt	Body	Passenger Presence Module																																																												
R	2014	Volt	Body	Instrument Cluster																																																												
R	2014	Volt	Body	Radio																																																												
R	2014	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Volt	Body	HVAC Control Module																																																												
R	2014	Volt	Body	Electric A/C Compressor Control Module																																																												
R	2014	Volt	Body	Coolant Heater Control Module																																																												
R	2014	Volt	Body	Front Seat Heating Control Module																																																												
R	2014	Volt	Body	Keyless Entry Control Module																																																												
R	2014	Volt	Body	Parking Assist Control Module																																																												
R	2014	Volt	Body	Frontview Camera Module																																																												
R	2014	Volt	Body	Steering Column Lock Control Module																																																												
R	2014	Volt	Body	Battery Charger Control Module																																																												
R	2014	Volt	Body	Battery Energy Control Module																																																												
R	2015	Volt	Powertrain	Engine Control Module																																																												
R	2015	Volt	Powertrain	Trasmission Control Module																																																												
R	2015	Volt	Powertrain	Chassis Control Module																																																												
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module																																																												
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																												
R	2015	Volt	Powertrain	Drive Motor Control Module 1																																																												
R	2015	Volt	Powertrain	Drive Motor Control Module 2																																																												
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																												
R	2015	Volt	Chassis	Electronic Brake Control Module																																																												
R	2015	Volt	Chassis	Parking Brake Control Module																																																												
R	2015	Volt	Chassis	Power Steering Control Module																																																												
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module																																																												
R	2015	Volt	Body	Body Control Module																																																												
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Volt	Body	Passenger Presence Module																																																												
R	2015	Volt	Body	Instrument Cluster																																																												
R	2015	Volt	Body	Radio																																																												
R	2015	Volt	Body	Digital Radio Receiver Control Module																																																												
R	2015	Volt	Body	Telematics Communication Interface Control Module																																																												
R	2015	Volt	Body	HVAC Control Module																																																												
R	2015	Volt	Body	Electric A/C Compressor Control Module																																																												
R	2015	Volt	Body	Coolant Heater Control Module																																																												
R	2015	Volt	Body	Front Seat Heating Control Module																																																												
R	2015	Volt	Body	Keyless Entry Control Module																																																												
R	2015	Volt	Body	Parking Assist Control Module																																																												
R	2015	Volt	Body	Frontview Camera Module																																																												
R	2015	Volt	Body	Steering Column Lock Control Module																																																												
R	2015	Volt	Body	Battery Charger Control Module																																																												
R	2015	Volt	Body	Battery Energy Control Module																																																												
R	2016	Volt	Powertrain	Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module																																										V	V	V											
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module 2																																													V									
R	2016	Volt	Powertrain	Drive Motor Control Module 1																																																						
R	2016	Volt	Powertrain	Drive Motor Control Module 2																																																						
R	2016	Volt	Chassis	Electronic Brake Control Module																																																						
R	2016	Volt	Chassis	Brake Booster Control Module																																																						
R	2016	Volt	Chassis	Power Steering Control Module																																																						
R	2016	Volt	Body	Body Control Module																																																						
R	2016	Volt	Body	Pedestrian Alert Sound Control Module																																																						
R	2016	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
R	2016	Volt	Body	Passenger Presence Module																																																						
R	2016	Volt	Body	Instrument Cluster																																																						
R	2016	Volt	Body	Radio Controls																																																						
R	2016	Volt	Body	HVAC Controls																																																						
R	2016	Volt	Body	Radio																																																						
R	2016	Volt	Body	Amplifier																																																						
R	2016	Volt	Body	Human Machine Interface Control Module																																																						
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 9.7																																																						
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 10																																																						
R	2016	Volt	Body	HVAC Control Module																																																						
R	2016	Volt	Body	Electric A/C Compressor Control Module																																																						
R	2016	Volt	Body	Keyless Entry Control Module																																																						
R	2016	Volt	Body	Right Side Object Detection Control Module																																																						
R	2016	Volt	Body	Left Side Object Detection Control Module																																																						
R	2016	Volt	Body	Parking Assist Control Module																																																						
R	2016	Volt	Body	Frontview Camera Module																																																						
R	2016	Volt	Body	Steering Column Lock Control Module																																																						
R	2016	Volt	Body	Battery Energy Control Module																																																						
R	2016	Volt	Body	Long Range Radar Sensor Module																																																						
S	2004	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																													V	V	V	V	V						
S	2004	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																						
S	2004	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																						
S	2004	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																						
S	2004	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																						
S	2004	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																						
S	2004	Aveo	Powertrain	Transmission Control Module																																																						
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																						
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																						
S	2004	Aveo	Body	Supplemental Inflatable Restraint																																																						
S	2004	Aveo	Body	Remote Function Actuation																																																					
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																													V	V	V	V	V						
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																					
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																													V	V	V	V	V						
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																					
S	2005	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																					
S	2005	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																					
S	2005	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																					
S	2005	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																					
S	2005	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																					
S	2005	Aveo	Powertrain	Transmission Control Module																																																					
S	2005	Aveo	Chassis	Electronic Brake Control Module																																																					

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2005	Aveo	Body	Supplemental Inflatable Restraint																																																										
S	2005	Aveo	Body	Remote Function Actuation																																																										
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																													V	V	V	V	V						
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																									
S	2006	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																									
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																									
S	2006	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																									
S	2006	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																									
S	2006	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
S	2006	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2006	Aveo	Body	Supplemental Inflatable Restraint																																																									
S	2006	Aveo	Body	Remote Function Actuation																																																									
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																													V	V	V	V	V						
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																									
S	2007	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																									
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																									
S	2007	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																									
S	2007	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																									
S	2007	Aveo	Powertrain	Transmission Control Module 4 Speed																																																									
S	2007	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
S	2007	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2007	Aveo	Body	Supplemental Inflatable Restraint																																																									
S	2007	Aveo	Body	Remote Function Actuation																																																									
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																													V	V	V	V	V						
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																									
S	2008	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																									
S	2008	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																									
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																									
S	2008	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																									
S	2008	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
S	2008	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																									
S	2008	Aveo	Powertrain	Transmission Control Module																																																									
S	2008	Aveo	Powertrain	Transmission Control Module																																																					V						
S	2008	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2008	Aveo	Chassis	Tire Pressure Monitor																																																									
S	2008	Aveo	Body	Supplemental Inflatable Restraint																																																									
S	2008	Aveo	Body	Remote Function Actuation																																																									
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																													V	V	V	V	V						
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																									
S	2009	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																									
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																									
S	2009	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																									
S	2009	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2009	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																												
S	2009	Aveo	Powertrain	Transmission Control Module																																																													
S	2009	Aveo	Powertrain	Transmission Control Module																																																							V				
S	2009	Aveo	Powertrain	Other Auto Transmission System																																																											
S	2009	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2009	Aveo	Chassis	Tire Pressure Monitor																																																											
S	2009	Aveo	Body	Supplemental Inflatable Restraint																																																											
S	2009	Aveo	Body	Remote Function Actuation																																																											
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																			V	V	V	V	V					
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																											
S	2010	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																											
S	2010	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
S	2010	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																											
S	2010	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
S	2010	Aveo	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
S	2010	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																											
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																						V				
S	2010	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2010	Aveo	Chassis	Tire Pressure Monitor																																																											
S	2010	Aveo	Body	Supplemental Inflatable Restraint																																																											
S	2010	Aveo	Body	Remote Function Actuation																																																											
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
S	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																											
S	2010	Sail	Powertrain	Transmission Control Module																																																											
S	2010	Sail	Chassis	Electronic Brake Control Module																																																											
S	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																			V	V	V	V	V					
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																											
S	2011	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																											
S	2011	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
S	2011	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																											
S	2011	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
S	2011	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																											
S	2011	Aveo	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																											
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																					V				
S	2011	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2011	Aveo	Chassis	Tire Pressure Monitor																																																											
S	2011	Aveo	Body	Supplemental Inflatable Restraint																																																											
S	2011	Aveo	Body	Remote Function Actuation																																																											
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																											
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																											
S	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																											
S	2011	Sail	Powertrain	Transmission Control Module																																																											
S	2011	Sail	Chassis	Electronic Brake Control Module																																																											
S	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																											
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																												
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
S	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																												
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
S	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																												
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
S	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																												
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
S	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
S	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
S	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																												
S	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
S	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																												
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
S	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																												
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																												
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																												
S	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																												
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																												
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																												
S	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																												
S	2012	Aveo	Powertrain	Fuel Pump Control Module																																																												
S	2012	Aveo	Powertrain	Fuel Injector Control Module																																																												
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2012	Aveo	Chassis	Electric Power Steering Control Module																																																												
S	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2012	Aveo	Chassis	Tire Pressure Monitor																																																												
S	2012	Aveo	Body	Body Control Module Hatchback																																																												
S	2012	Aveo	Body	Body Control Module Sedan																																																												
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2012	Aveo	Body	Passenger Presence Module																																																												
S	2012	Aveo	Body	Instrument Cluster																																																												
S	2012	Aveo	Body	Radio																																																											
S	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																												
S	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
S	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
S	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
S	2012	Aveo	Body	Front Seat Heating Control Module																																																												
S	2012	Aveo	Body	Remote Function Actuation																																																												
S	2012	Aveo	Body	Parking Assist Control Module																																																												
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																	V	V	V	V	V					

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																											
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																												
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																												
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																												
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																												
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																												
S	2012	Sail	Powertrain	Transmission Control Module																																																												
S	2012	Sail	Chassis	Electronic Brake Control Module																																																												
S	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																												
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																												
S	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																												
S	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																												
S	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																												
S	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																												
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
S	2013	Aveo	Powertrain	Fuel Injector Control Module																																																												
S	2013	Aveo	Powertrain	Fuel Pump Control Module																																																												
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																												
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								V				
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2013	Aveo	Chassis	Electric Power Steering Control Module																																																												
S	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2013	Aveo	Body	Body Control Module Hatchback																																																												
S	2013	Aveo	Body	Body Control Module Sedan																																																												
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2013	Aveo	Body	Passenger Presence Module																																																												
S	2013	Aveo	Body	Instrument Cluster																																																												
S	2013	Aveo	Body	Radio																																																											
S	2013	Aveo	Body	Telematics Communication Interface Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
S	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
S	2013	Aveo	Body	Front Seat Heating Control Module																																																											
S	2013	Aveo	Body	Remote Function Actuation																																																											
S	2013	Aveo	Body	Parking Assist Control Module																																																											
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
S	2013	Sail	Powertrain	Transmission Control Module																																																											
S	2013	Sail	Chassis	Electronic Brake Control Module																																																											
S	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																											
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																											
S	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																											
S	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																											
S	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																											
S	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
S	2014	Aveo	Powertrain	Chassis Control Module																																																											
S	2014	Aveo	Powertrain	Fuel Injector Control Module																																																											
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																											
S	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2014	Aveo	Chassis	Power Steering Control Module																																																											
S	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2014	Aveo	Body	Body Control Module Hatchback																																																											
S	2014	Aveo	Body	Body Control Module Sedan																																																											
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2014	Aveo	Body	Instrument Cluster																																																											
S	2014	Aveo	Body	Radio																																																											
S	2014	Aveo	Body	Telematics Communication Interface Control Module																																																											
S	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
S	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
S	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
S	2014	Aveo	Body	Front Seat Heating Control Module																																																											
S	2014	Aveo	Body	Keyless Entry Control Module																																																											
S	2014	Aveo	Body	Parking Assist Control Module																																																											
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
S	2014	Sail	Powertrain	Transmission Control Module																																																											
S	2014	Sail	Chassis	Electronic Brake Control Module																																																											
S	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																											
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																											
S	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
S	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																												
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
S	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																												
S	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																												
S	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																												
S	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																												
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																												
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																												
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																												
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																												
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																												
S	2015	Aveo	Powertrain	Chassis Control Module																																																												
S	2015	Aveo	Powertrain	Fuel Injector Control Module																																																												
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																												
S	2015	Aveo	Chassis	Power Steering Control Module																																																												
S	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2015	Aveo	Body	Body Control Module Hatchback																																																												
S	2015	Aveo	Body	Body Control Module Sedan																																																												
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2015	Aveo	Body	Instrument Cluster																																																												
S	2015	Aveo	Body	Radio																																																											
S	2015	Aveo	Body	Telematics Communication Interface Control Module																																																												
S	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																												
S	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
S	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																												
S	2015	Aveo	Body	Front Seat Heating Control Module																																																												
S	2015	Aveo	Body	Keyless Entry Control Module																																																												
S	2015	Aveo	Body	Parking Assist Control Module																																																												
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																												
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																												
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																												
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																												
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																												
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																												
S	2015	Sail	Powertrain	Transmission Control Module																																																												
S	2015	Sail	Chassis	Electronic Brake Control Module																																																												
S	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																												
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																												
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
S	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
S	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
S	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
S	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
S	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
S	2016	Aveo	Powertrain	Chassis Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																										
S	2016	Aveo	Chassis	Power Steering Control Module																																																										
S	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	Aveo	Body	Body Control Module Hatchback																																																										
S	2016	Aveo	Body	Body Control Module Sedan																																																										
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Aveo	Body	Instrument Cluster																																																										
S	2016	Aveo	Body	Radio																																																										
S	2016	Aveo	Body	Telematics Communication Interface Control Module																																																										
S	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
S	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
S	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
S	2016	Aveo	Body	Front Seat Heating Control Module																																																										
S	2016	Aveo	Body	Parking Assist Control Module																																																										
S	2016	Aveo	Body	Keyless Entry Control Module																																																										
S	2016	Aveo	Body	Frontview Camera Module																																																										
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																										
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
S	2016	Sail	Powertrain	Transmission Control Module																																																										
S	2016	Sail	Chassis	Electronic Brake Control Module																																																										
S	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2004	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2004	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2004	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
T	2004	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2004	ALL	Powertrain	Transmission Control Module																																																										
T	2004	ALL	Chassis	Electronic Brake Control Module																																																										
T	2004	ALL	Chassis	Electronic Brake Control Module																																																										
T	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2004	ALL	Body	Remote Function Actuation																																																										
T	2005	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2005	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2005	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
T	2005	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2005	ALL	Powertrain	Transmission Control Module																																																										
T	2005	ALL	Chassis	Electronic Brake Control Module																																																										
T	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2005	ALL	Body	Remote Function Actuation																																																										
T	2006	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
T	2006	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
T	2006	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
T	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2006	ALL	Chassis	Electronic Brake Control Module																																																										
T	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2006	ALL	Body	Remote Function Actuation																																																										
T	2007	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																										
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										
T	2007	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																										
T	2007	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																										
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																										
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																										
T	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
T	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																										
T	2007	ALL	Chassis	Electronic Brake Control Module																																																										
T	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2007	ALL	Body	Remote Function Actuation																																																										
T	2008	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																										
T	2008	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																										
T	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2008	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																								
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
T	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																								
T	2008	ALL	Powertrain	Transmission Control Module																																																								
T	2008	ALL	Powertrain	Transmission Control Module																																																			V				
T	2008	ALL	Chassis	Electronic Brake Control Module																																																							
T	2008	ALL	Chassis	Tire Pressure Monitor																																																							
T	2008	ALL	Body	Supplemental Inflatable Restraint																																																							
T	2008	ALL	Body	Remote Function Actuation																																																						
T	2008	ALL	Body	Passenger Presence System																																																						
T	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																						
T	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																						
T	2009	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																						
T	2009	ALL	Powertrain	Transmission Control Module																																																						
T	2009	ALL	Powertrain	Transmission Control Module																																																			V				
T	2009	ALL	Chassis	Electronic Brake Control Module																																																						
T	2009	ALL	Chassis	Tire Pressure Monitor																																																						
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																						
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																						
T	2009	ALL	Body	Instrument Panel Cluster																																																			V			
T	2009	ALL	Body	Passenger Presence System																																																						
T	2009	ALL	Body	Theft Deterrent Module																																																						
T	2009	ALL	Body	Radio																																																						
T	2009	ALL	Body	Remote Function Actuation																																																						
T	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																						
T	2010	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																						
T	2010	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																						
T	2010	ALL	Powertrain	Transmission Control Module																																																						
T	2010	ALL	Powertrain	Transmission Control Module																																																			V			
T	2010	ALL	Chassis	Electronic Brake Control Module																																																						
T	2010	ALL	Chassis	Tire Pressure Monitor																																																						
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																						
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																						
T	2010	ALL	Body	Instrument Panel Cluster																																																			V			
T	2010	ALL	Body	Passenger Presence System																																																						
T	2010	ALL	Body	Theft Deterrent Module																																																						
T	2010	ALL	Body	Radio																																																						
T	2010	ALL	Body	Remote Function Actuation																																																						
T	2011	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																						
T	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																						
T	2011	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																						
T	2011	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																						
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																						
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module Argentia																																																						
T	2011	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																						
T	2011	ALL	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																						
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																						
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																				V			
T	2011	ALL	Chassis	Electronic Brake Control Module																																																						
T	2011	ALL	Chassis	Tire Pressure Monitor																																																						

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2011	ALL	Body	Instrument Panel Cluster																																																						V			
T	2011	ALL	Body	Passenger Presence System																																																								
T	2011	ALL	Body	Theft Deterrent Module																																																								
T	2011	ALL	Body	Radio																																																								
T	2011	ALL	Body	Remote Function Actuation																																																								
T	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																								
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
T	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
T	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																								
T	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
T	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																								
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
T	2012	Aveo	Powertrain	Fuel Injector Control Module																																																								
T	2012	Aveo	Powertrain	Fuel Pump Control Module																																																								
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2012	Aveo	Chassis	Electric Power Steering Control Module																																																								
T	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2012	Aveo	Chassis	Tire Pressure Monitor																																																								
T	2012	Aveo	Body	Body Control Module Hatchback																																																								
T	2012	Aveo	Body	Body Control Module Sedan																																																								
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	Aveo	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2012	Aveo	Body	Instrument Cluster																																																											
T	2012	Aveo	Body	Radio																																																											
T	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																											
T	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
T	2012	Aveo	Body	Front Seat Heating Control Module																																																											
T	2012	Aveo	Body	Remote Function Actuation																																																											
T	2012	Aveo	Body	Parking Assist Control Module																																																											
T	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																											
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
T	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																											
T	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																											
T	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																											
T	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
T	2013	Aveo	Powertrain	Fuel Injector Control Module																																																											
T	2013	Aveo	Powertrain	Fuel Pump Control Module																																																											
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																											
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2013	Aveo	Chassis	Electric Power Steering Control Module																																																											
T	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2013	Aveo	Body	Body Control Module Hatchback																																																											
T	2013	Aveo	Body	Body Control Module Sedan																																																											
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	Aveo	Body	Passenger Presence Module																																																											
T	2013	Aveo	Body	Instrument Cluster																																																											
T	2013	Aveo	Body	Radio																																																											
T	2013	Aveo	Body	Telematics Communication Interface Control Module																																																											
T	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2013	Aveo	Body	Front Seat Heating Control Module																																																										
T	2013	Aveo	Body	Remote Function Actuation																																																										
T	2013	Aveo	Body	Parking Assist Control Module																																																										
T	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																										
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
T	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
T	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
T	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
T	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
T	2014	Aveo	Powertrain	Chassis Control Module																																																										
T	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	Aveo	Chassis	Power Steering Control Module																																																										
T	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	Aveo	Body	Body Control Module Hatchback																																																										
T	2014	Aveo	Body	Body Control Module Sedan																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2014	Aveo	Body	Instrument Cluster																																																												
T	2014	Aveo	Body	Radio																																																											
T	2014	Aveo	Body	Telematics Communication Interface Control Module																																																											
T	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
T	2014	Aveo	Body	Front Seat Heating Control Module																																																											
T	2014	Aveo	Body	Keyless Entry Control Module																																																											
T	2014	Aveo	Body	Parking Assist Control Module																																																											
T	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																											
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																											
T	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																											
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																											
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																											
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																											
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																											
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
T	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																											
T	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																											
T	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																											
T	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																											
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																											
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																											
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																											
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																											
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																											
T	2015	Aveo	Powertrain	Chassis Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2015	Aveo	Powertrain	Fuel Injector Control Module																																																										
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																										
T	2015	Aveo	Chassis	Power Steering Control Module																																																										
T	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2015	Aveo	Body	Body Control Module Hatchback																																																										
T	2015	Aveo	Body	Body Control Module Sedan																																																										
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Aveo	Body	Instrument Cluster																																																										
T	2015	Aveo	Body	Radio																																																										
T	2015	Aveo	Body	Telematics Communication Interface Control Module																																																										
T	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
T	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
T	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
T	2015	Aveo	Body	Front Seat Heating Control Module																																																										
T	2015	Aveo	Body	Keyless Entry Control Module																																																										
T	2015	Aveo	Body	Parking Assist Control Module																																																										
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																										
T	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																										
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																										
T	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																										
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																										
T	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																										
T	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
T	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
T	2016	Aveo	Powertrain	Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																											
T	2016	Aveo	Chassis	Power Steering Control Module																																																											
T	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2016	Aveo	Body	Body Control Module Hatchback																																																											
T	2016	Aveo	Body	Body Control Module Sedan																																																											
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2016	Aveo	Body	Instrument Cluster																																																											
T	2016	Aveo	Body	Radio																																																											
T	2016	Aveo	Body	Telematics Communication Interface Control Module																																																											
T	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
T	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																											
T	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																											
T	2016	Aveo	Body	Front Seat Heating Control Module																																																											
T	2016	Aveo	Body	Parking Assist Control Module																																																											
T	2016	Aveo	Body	Keyless Entry Control Module																																																											
T	2016	Aveo	Body	Frontview Camera Module																																																											
U	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2004	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																											
U	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2004	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																											
U	2004	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
U	2004	ALL	Chassis	Electronic Brake Control Module																																																											
U	2004	ALL	Chassis	Electronic Brake Control Module																																																											
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2004	ALL	Body	Remote Function Actuation																																																											
U	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2005	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																											
U	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2005	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																											
U	2005	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																											
U	2005	ALL	Chassis	Electronic Brake Control Module																																																											
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2005	ALL	Body	Remote Function Actuation																																																											
U	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2006	ALL	Powertrain	Transmission Control Module																																																											
U	2006	ALL	Chassis	Electronic Brake Control Module																																																											
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2006	ALL	Body	Remote Function Actuation																																																											
U	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2007	ALL	Powertrain	Transmission Control Module																																																											
U	2007	ALL	Chassis	Electronic Brake Control Module																																																											
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
U	2007	ALL	Body	Remote Function Actuation																																																											
U	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																											
U	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																											
U	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																											
U	2008	ALL	Powertrain	Transmission Control Module																																																											
U	2008	ALL	Chassis	Electronic Brake Control Module																																																											
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2008	ALL	Body	Remote Function Actuation																																																											
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
U	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																											
U	2010	Sail	Powertrain	Transmission Control Module																																																											
U	2010	Sail	Chassis	Electronic Brake Control Module																																																											
U	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																											
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																											
U	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																											
U	2011	Sail	Powertrain	Transmission Control Module																																																											
U	2011	Sail	Chassis	Electronic Brake Control Module																																																											
U	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																											
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																											
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																											
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																											
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
U	2012	Sail	Powertrain	Transmission Control Module																																																											
U	2012	Sail	Chassis	Electronic Brake Control Module																																																											
U	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																											
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																											
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
U	2013	Sail	Powertrain	Transmission Control Module																																																											
U	2013	Sail	Chassis	Electronic Brake Control Module																																																											
U	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																											
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																											
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																											
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																											
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																											
U	2014	Sail	Powertrain	Transmission Control Module																																																											
U	2014	Sail	Chassis	Electronic Brake Control Module																																																											
U	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																									
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
U	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																									
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																									
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																									
U	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																									
U	2015	Sail	Powertrain	Transmission Control Module																																																									
U	2015	Sail	Chassis	Electronic Brake Control Module																																																									
U	2015	Sail	Chassis	Electronic Brake Control Module																																																									
U	2015	Sail	Chassis	Power Steering Control Module																																																									
U	2015	Sail	Body	Body Control Module																																																									
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
U	2015	Sail	Body	Radio/HVAC Control																																																									
U	2015	Sail	Body	HVAC Control Module																																																									
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																									
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																									
U	2016	Sail	Powertrain	1.2L LMU Transmission Control Module																																																									
U	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																									
U	2016	Sail	Powertrain	1.3L LDV Transmission Control Module																																																									
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																									
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																									
U	2016	Sail	Powertrain	1.4L LCU Transmission Control Module																																																									
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																									
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																									
U	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																									
U	2016	Sail	Chassis	Electronic Brake Control Module																																																									
U	2016	Sail	Chassis	Electronic Brake Control Module																																																									
U	2016	Sail	Chassis	Power Steering Control Module																																																									
U	2016	Sail	Body	Body Control Module																																																									
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
U	2016	Sail	Body	Radio/HVAC Control																																																									
U	2016	Sail	Body	Radio																																																									
U	2016	Sail	Body	HVAC Control Module																																																									
V	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
V	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module												V	V	V	V																																										
V	2004	ALL	Powertrain	Transmission Control Module 4 Speed																																																									
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																V																																									
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																									
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2004	ALL	Body	ISU																		V	V																																						
V	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
V	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module												V	V	V	V																																										
V	2005	ALL	Powertrain	Transmission Control Module 4 Speed																																																									
V	2005	ALL	Chassis	Electronic Brake Control Module																																																									
V	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2005	ALL	Body	ISU																		V	V																																						
V	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
V	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module												V	V	V	V																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
V	2006	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																										
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																										
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2006	ALL	Body	ISU																			V	V																																						
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																					V	V																																				
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector Control Module																																																										
V	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																										
V	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																							V																																			
V	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																					V	V																																				
V	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																					V	V																																				
V	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																										
V	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																										
V	2007	ALL	Chassis	Electronic Brake Control Module																																																										
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2007	ALL	Body	ISU																			V	V																																						
V	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																						V		V	V	V																																
V	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																						V		V	V	V																																
V	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																										
V	2008	ALL	Chassis	Electronic Brake Control Module																																																										
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2008	ALL	Body	ISU																			V	V																																						
V	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																						V		V	V	V																																
V	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																						V		V	V	V																																
V	2009	ALL	Powertrain	Transmission Control Module 6 Speed																											V	V																													
V	2009	ALL	Chassis	Electronic Brake Control Module																																																										
V	2009	ALL	Body	ISU																			V	V																																						
V	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																										
V	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																						V		V	V	V																																
V	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																						V		V	V	V																																
V	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																										
V	2010	ALL	Chassis	Electronic Brake Control Module																																																										
V	2010	ALL	Body	ISU																			V	V																																						
V	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																										
V	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																						V		V	V	V																																
V	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																						V		V	V	V																																
V	2011	ALL	Powertrain	Transmission Control Module 6 Speed																											V	V																													
V	2011	ALL	Chassis	Electronic Brake Control Module																																																										
V	2011	ALL	Body	ISU																			V	V																																						
W	2004	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																								V																	
W	2004	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																								V																	
W	2004	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																								V																	
W	2004	ALL	Powertrain	Transmission Control Module																																																										
W	2004	ALL	Body	Body Control Module																																																								V	V	V
W	2004	ALL	Body	Digital Radio Receiver																																																										
W	2004	ALL	Body	Driver Information Center																																																										
W	2004	ALL	Body	Heating and Air Conditioning																																																										
W	2004	ALL	Body	Instrument Panel Cluster																																																										
W	2004	ALL	Body	Personalization																																																										
W	2004	ALL	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
W	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																								V																	
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																								V																	
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																								V																	
W	2005	ALL	Powertrain	Transmission Control Module																																																								
W	2005	ALL	Body	Body Control Module																																																							V	V	V
W	2005	ALL	Body	Digital Radio Receiver																																																								
W	2005	ALL	Body	Driver Information Center																																																								
W	2005	ALL	Body	Heating and Air Conditioning																																																								
W	2005	ALL	Body	Instrument Panel Cluster																																																								
W	2005	ALL	Body	Personalization																																																								
W	2005	ALL	Body	Radio																																																								
W	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																								
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																								
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																								
W	2006	ALL	Powertrain	Transmission Control Module																																																								
W	2006	ALL	Chassis	Anti-lock Brake System																																																								
W	2006	ALL	Body	Digital Radio Receiver																																																								
W	2006	ALL	Body	Radio																																																								
W	2006	ALL	Body	Instrument Panel Cluster																																																								
W	2006	ALL	Body	Seat																																																								
W	2006	ALL	Body	Theft Deterrent Module																																																								
W	2006	ALL	Body	Body Control Module																																																								
W	2006	ALL	Body	HVAC C67 Single																																																								
W	2006	ALL	Body	HVAC CJ3 Dual																																																								
W	2006	ALL	Body	Remote Control Door Lock Receiver																																																								
W	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
W	2006	ALL	Body	Passenger Presence System																																																								
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																								
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																								
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																								
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module																																																								
W	2007	ALL	Powertrain	Transmission Control Module																																																								
W	2007	ALL	Chassis	Electronic Brake Control Module																																																								
W	2007	ALL	Body	Body Control Module																																																								
W	2007	ALL	Body	Digital Radio Receiver																																																								
W	2007	ALL	Body	Heated Seat Module																																																								
W	2007	ALL	Body	HVAC C67 Single																																																								
W	2007	ALL	Body	HVAC CJ3 Dual																																																								
W	2007	ALL	Body	Instrument Panel Cluster																																																								
W	2007	ALL	Body	Passenger Presence System																																																								
W	2007	ALL	Body	Radio																																																								
W	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
W	2007	ALL	Body	Theft Deterrent Module																																					V	V																		
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																								
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																								
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module																																																								
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																								
W	2008	ALL	Powertrain	Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
W	2008	ALL	Chassis	Electronic Brake Control Module																																																											
W	2008	ALL	Body	Body Control Module																																																											
W	2008	ALL	Body	Digital Radio Receiver																																																											
W	2008	ALL	Body	Heated Seat Module																																																											
W	2008	ALL	Body	HVAC C67 Single																																																											
W	2008	ALL	Body	HVAC CJ3 Dual																																																											
W	2008	ALL	Body	Instrument Panel Cluster																																																											
W	2008	ALL	Body	Passenger Presence System																																																											
W	2008	ALL	Body	Radio																																																											
W	2008	ALL	Body	Remote Control Door Lock Receiver																																																											
W	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
W	2008	ALL	Body	Theft Deterrent Module																																					V	V																					
W	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
W	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
W	2009	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																											
W	2009	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module																																																											
W	2009	ALL	Powertrain	Transmission Control Module																																																											
W	2009	ALL	Chassis	Electronic Brake Control Module																																																											
W	2009	ALL	Body	Body Control Module																																																											
W	2009	ALL	Body	Digital Radio Receiver																																																											
W	2009	ALL	Body	Heated Seat Module																																																											
W	2009	ALL	Body	HVAC C67 Single																																																											
W	2009	ALL	Body	HVAC CJ3 Dual																																																											
W	2009	ALL	Body	Instrument Panel Cluster																																																											
W	2009	ALL	Body	Passenger Presence System																																																											
W	2009	ALL	Body	Radio																																																											
W	2009	ALL	Body	Remote Control Door Lock Receiver																																																											
W	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
W	2009	ALL	Body	Theft Deterrent Module																																					V	V																					
W	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																											
W	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
W	2010	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																											
W	2010	ALL	Powertrain	Transmission Control Module																																																											
W	2010	ALL	Chassis	Electronic Brake Control Module																																																											
W	2010	ALL	Body	Body Control Module																																																											
W	2010	ALL	Body	Digital Radio Receiver																																																											
W	2010	ALL	Body	Heated Seat Module																																																											
W	2010	ALL	Body	HVAC C67 Single																																																											
W	2010	ALL	Body	HVAC CJ3 Dual																																																											
W	2010	ALL	Body	Instrument Panel Cluster																																																											
W	2010	ALL	Body	Passenger Presence System																																																											
W	2010	ALL	Body	Radio																																																											
W	2010	ALL	Body	Remote Control Door Lock Receiver																																																											
W	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
W	2010	ALL	Body	Theft Deterrent Module																																					V	V																					
W	2011	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																											
W	2011	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module																																																											
W	2011	ALL	Powertrain	Transmission Control Module																																																											
W	2011	ALL	Chassis	Electronic Brake Control Module																																																											
W	2011	ALL	Body	Body Control Module																																																											
W	2011	ALL	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
W	2011	ALL	Body	Heated Seat Module																																																									
W	2011	ALL	Body	HVAC C67 Single																																																									
W	2011	ALL	Body	HVAC CJ3 Dual																																																									
W	2011	ALL	Body	Instrument Panel Cluster																																																									
W	2011	ALL	Body	Passenger Presence System																																																									
W	2011	ALL	Body	Radio																																																									
W	2011	ALL	Body	Remote Control Door Lock Receiver																																																									
W	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
W	2011	ALL	Body	Theft Deterrent Module																																						V	V																		
W	2012	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																									
W	2012	ALL	Powertrain	Transmission Control Module																																																									
W	2012	ALL	Powertrain	Fuel Pump Control Module																																																									
W	2012	ALL	Chassis	Electronic Brake Control Module																																																									
W	2012	ALL	Body	Body Control Module																																																									
W	2012	ALL	Body	Digital Radio Receiver																																																									
W	2012	ALL	Body	Heated Seat Module																																																									
W	2012	ALL	Body	HVAC C67 Single																																																									
W	2012	ALL	Body	HVAC CJ3 Dual																																																									
W	2012	ALL	Body	Instrument Panel Cluster																																																									
W	2012	ALL	Body	Passenger Presence System																																																									
W	2012	ALL	Body	Radio																																																									
W	2012	ALL	Body	Remote Control Door Lock Receiver																																																									
W	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
W	2012	ALL	Body	Theft Deterrent Module																																						V	V																		
W	2013	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																									
W	2013	ALL	Powertrain	Transmission Control Module																																																									
W	2013	ALL	Powertrain	Fuel Pump Control Module																																																									
W	2013	ALL	Chassis	Electronic Brake Control Module																																																									
W	2013	ALL	Body	Body Control Module																																																									
W	2013	ALL	Body	Digital Radio Receiver																																																									
W	2013	ALL	Body	Heated Seat Module																																																									
W	2013	ALL	Body	HVAC C67 Single																																																									
W	2013	ALL	Body	HVAC CJ3 Dual																																																									
W	2013	ALL	Body	Instrument Panel Cluster																																																									
W	2013	ALL	Body	Passenger Presence System																																																									
W	2013	ALL	Body	Radio																																																									
W	2013	ALL	Body	Remote Control Door Lock Receiver																																																									
W	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
W	2013	ALL	Body	Theft Deterrent Module																																						V	V																		
W	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
W	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
W	2014	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																									
W	2014	Impala	Chassis	Electronic Brake Control Module																																																									
W	2014	Impala	Body	Body Control Module																																																									
W	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
W	2014	Impala	Body	Passenger Presence Module																																																									
W	2014	Impala	Body	Instrument Cluster																																																									
W	2014	Impala	Body	Radio																																																									
W	2014	Impala	Body	Digital Radio Receiver Control Module																																																									
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																									
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
W	2014	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
W	2014	Impala	Body	HVAC Manual Control Single Zone (C67)																																																											
W	2014	Impala	Body	Front Seat Heating Control Module																																																											
W	2014	Impala	Body	Remote Control Door Lock Receiver																																																											
W	2014	Impala	Body	Theft Deterrent Module																																																											
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																											
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																											
W	2014	Lumina	Powertrain	(2) 6.0L L77 Transmission Control Module																																																											
W	2014	Lumina	Powertrain	Fuel Injector Control Module																																																											
W	2014	Lumina	Powertrain	Chassis Control Module																																																											
W	2014	Lumina	Chassis	Electronic Brake Control Module																																																											
W	2014	Lumina	Chassis	Parking Brake Control Module																																																											
W	2014	Lumina	Chassis	Power Steering Control Module																																																											
W	2014	Lumina	Chassis	Steering Wheel Angle Sensor Module																																																											
W	2014	Lumina	Chassis	Suspension Control Module																																																											
W	2014	Lumina	Body	Body Control Module Coupe																																																											
W	2014	Lumina	Body	Body Control Module Sedan																																																											
W	2014	Lumina	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
W	2014	Lumina	Body	Instrument Cluster																																																											
W	2014	Lumina	Body	Head-Up Display Module																																																											
W	2014	Lumina	Body	Radio Control																																																											
W	2014	Lumina	Body	HVAC Control																																																											
W	2014	Lumina	Body	Headlamp Control Module																																																											
W	2014	Lumina	Body	Trailer Interface Control Module																																																											
W	2014	Lumina	Body	Radio																																																											
W	2014	Lumina	Body	HVAC Control Module																																																											
W	2014	Lumina	Body	Keyless Entry Control Module																																																											
W	2014	Lumina	Body	Right Side Object Detection Control Module																																																											
W	2014	Lumina	Body	Left Side Object Detection Control Module																																																											
W	2014	Lumina	Body	Parking Assist Control Module																																																											
W	2014	Lumina	Body	Frontview Camera Module																																																											
W	2014	Lumina	Body	Steering Column Lock Control Module																																																											
W	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
W	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
W	2015	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																											
W	2015	Impala	Chassis	Electronic Brake Control Module																																																											
W	2015	Impala	Body	Body Control Module																																																											
W	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
W	2015	Impala	Body	Passenger Presence Module																																																											
W	2015	Impala	Body	Instrument Cluster																																																											
W	2015	Impala	Body	Radio																																																											
W	2015	Impala	Body	Digital Radio Receiver Control Module																																																											
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 9																																																											
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 10																																																											
W	2015	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
W	2015	Impala	Body	HVAC Manual Control Single Zone (C67)																																																											
W	2015	Impala	Body	Front Seat Heating Control Module																																																											
W	2015	Impala	Body	Remote Control Door Lock Receiver																																																											
W	2015	Impala	Body	Theft Deterrent Module																																																											
W	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
W	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
W	2016	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
W	2016	Impala	Chassis	Electronic Brake Control Module																																																											
W	2016	Impala	Body	Body Control Module																																																										
W	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2016	Impala	Body	Passenger Presence Module																																																										
W	2016	Impala	Body	Instrument Cluster																																																										
W	2016	Impala	Body	Radio																																																										
W	2016	Impala	Body	Digital Radio Receiver Control Module																																																										
W	2016	Impala	Body	Telematics Communication Interface Control Module																																																										
W	2016	Impala	Body	HVAC Manual Control Dual Zone (CJ2)																																																										
W	2016	Impala	Body	HVAC Manual Control Single Zone (C67)																																																										
W	2016	Impala	Body	Front Seat Heating Control Module																																																										
W	2016	Impala	Body	Remote Control Door Lock Receiver																																																										
W	2016	Impala	Body	Theft Deterrent Module																																																										
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Auto																																																										
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Manual																																																										
Y	2004	ALL	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																										
Y	2004	ALL	Powertrain	Transmission Control Module																																																										
Y	2004	ALL	Chassis	RTD																																																										
Y	2004	ALL	Body	Body Control Module																																	V	V																							
Y	2004	ALL	Body	Heating and Air Conditioning																																																										
Y	2004	ALL	Body	Instrument Panel Cluster																																																										
Y	2004	ALL	Body	Left Door Control Module																																																										
Y	2004	ALL	Body	Radio																																																										
Y	2004	ALL	Body	Remote Function Actuation																																																										
Y	2004	ALL	Body	Right Door Control Module																																																										
Y	2004	ALL	Body	Seat Control Module																																																										
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2005	ALL	Powertrain	Engine Control Module																																																										
Y	2005	ALL	Powertrain	Transmission Control Module																																																										
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2005	ALL	Chassis	Electronic Suspension Control																																																										
Y	2005	ALL	Chassis	Steering Wheel and Column																																																										
Y	2005	ALL	Body	Amplifier																																																									
Y	2005	ALL	Body	Body Control Module																																																									
Y	2005	ALL	Body	Digital Radio Receiver																																																										
Y	2005	ALL	Body	Driver Door Module																																																										
Y	2005	ALL	Body	Driver Door Switch																																																										
Y	2005	ALL	Body	Driver Position Module																																																										
Y	2005	ALL	Body	Folding Top Module																																																										
Y	2005	ALL	Body	Head Up Display																																																										
Y	2005	ALL	Body	HVAC Control Module																																																										
Y	2005	ALL	Body	Instrument Panel Cluster																																																										
Y	2005	ALL	Body	Navigation Radio																																																										
Y	2005	ALL	Body	Passenger Door Module																																																										
Y	2005	ALL	Body	Radio																																																										
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2006	ALL	Powertrain	Engine Control Module																																																										
Y	2006	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2006	ALL	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
Y	2006	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2006	ALL	Chassis	Electronic Suspension Control																																																											
Y	2006	ALL	Chassis	Steering Wheel and Column																																																											
Y	2006	ALL	Body	Body Control Module																																																										
Y	2006	ALL	Body	CD Changer																																																										
Y	2006	ALL	Body	Digital Radio Receiver																																																										
Y	2006	ALL	Body	Driver Door Module																																																										
Y	2006	ALL	Body	Driver Door Switch																																																										
Y	2006	ALL	Body	Driver Position Module																																																										
Y	2006	ALL	Body	Folding Top Module																																																										
Y	2006	ALL	Body	Head Up Display																																																										
Y	2006	ALL	Body	HVAC Control Module																																																										
Y	2006	ALL	Body	Instrument Panel Cluster																																																										
Y	2006	ALL	Body	Navigation Radio																																																										
Y	2006	ALL	Body	Passenger Door Module																																																										
Y	2006	ALL	Body	Radio																																																										
Y	2006	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2007	ALL	Powertrain	Engine Control Module																																																										
Y	2007	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	ALL	Powertrain	Transmission Control Module																																																										
Y	2007	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2007	ALL	Chassis	Electronic Suspension Control																																																										
Y	2007	ALL	Body	Body Control Module																																																										
Y	2007	ALL	Body	CD Changer																																																										
Y	2007	ALL	Body	Digital Radio Receiver																																																										
Y	2007	ALL	Body	Driver Door Module																																																										
Y	2007	ALL	Body	Driver Door Switch																																																										
Y	2007	ALL	Body	Driver Position Module																																																										
Y	2007	ALL	Body	Folding Top Module																																																										
Y	2007	ALL	Body	Head Up Display																																																										
Y	2007	ALL	Body	HVAC Control Module																																																										
Y	2007	ALL	Body	Instrument Panel Cluster																																																										
Y	2007	ALL	Body	Navigation Radio																																																										
Y	2007	ALL	Body	Passenger Door Module																																																										
Y	2007	ALL	Body	Radio																																																										
Y	2007	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2007	ALL	Body	Steering Column Lock Module																																																										
Y	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2008	ALL	Powertrain	Engine Control Module																																																										
Y	2008	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2008	ALL	Powertrain	Transmission Control Module																																																										
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2008	ALL	Chassis	Electronic Suspension Control																																																										
Y	2008	ALL	Body	Body Control Module																																																										
Y	2008	ALL	Body	CD Changer																																																										
Y	2008	ALL	Body	Digital Radio Receiver																																																										
Y	2008	ALL	Body	Driver Door Module																																																										
Y	2008	ALL	Body	Driver Door Switch																																																										
Y	2008	ALL	Body	Driver Position Module																																																										
Y	2008	ALL	Body	Folding Top Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
Y	2008	ALL	Body	Head Up Display																																																									
Y	2008	ALL	Body	HVAC Control Module																																																									
Y	2008	ALL	Body	Instrument Panel Cluster																																																									
Y	2008	ALL	Body	Navigation Radio																																																									
Y	2008	ALL	Body	Passenger Door Module																																																									
Y	2008	ALL	Body	Radio																																																									
Y	2008	ALL	Body	Personal Audio Link Module																																																									
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																									
Y	2008	ALL	Body	Steering Column Lock Module																																																									
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																									
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																									
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																									
Y	2009	ALL	Chassis	Electronic Brake Control Module																																																									
Y	2009	ALL	Chassis	Electronic Suspension Control																																																									
Y	2009	ALL	Body	Body Control Module																																																									
Y	2009	ALL	Body	CD Changer																																																									
Y	2009	ALL	Body	Digital Radio Receiver																																																									
Y	2009	ALL	Body	Driver Door Module																																																									
Y	2009	ALL	Body	Driver Door Switch																																																									
Y	2009	ALL	Body	Driver Position Module																																																									
Y	2009	ALL	Body	Folding Top Module																																																									
Y	2009	ALL	Body	Head Up Display																																																									
Y	2009	ALL	Body	HVAC Control Module																																																									
Y	2009	ALL	Body	Instrument Panel Cluster																																																									
Y	2009	ALL	Body	Navigation Radio																																																									
Y	2009	ALL	Body	Passenger Door Module																																																									
Y	2009	ALL	Body	Radio																																																									
Y	2009	ALL	Body	Personal Audio Link Module																																																									
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																																									
Y	2009	ALL	Body	Steering Column Lock Module																																																									
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																									
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																									
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																									
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																									
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																									
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																									
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																									
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																									
Y	2010	ALL	Chassis	Electronic Brake Control Module																																																									
Y	2010	ALL	Chassis	Electronic Suspension Control																																																									
Y	2010	ALL	Body	Body Control Module																																																									
Y	2010	ALL	Body	CD Changer																																																									
Y	2010	ALL	Body	Digital Radio Receiver																																																									
Y	2010	ALL	Body	Driver Door Module																																																									
Y	2010	ALL	Body	Driver Door Switch																																																									
Y	2010	ALL	Body	Driver Position Module																																																									
Y	2010	ALL	Body	Folding Top Module																																																									
Y	2010	ALL	Body	Head Up Display																																																									
Y	2010	ALL	Body	HVAC Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
Y	2010	ALL	Body	Instrument Panel Cluster																																																											
Y	2010	ALL	Body	Navigation Radio																																																											
Y	2010	ALL	Body	Passenger Door Module																																																											
Y	2010	ALL	Body	Radio																																																											
Y	2010	ALL	Body	Personal Audio Link Module																																																											
Y	2010	ALL	Body	Remote Control Door Lock Receiver																																																											
Y	2010	ALL	Body	Steering Column Lock Module																																																											
Y	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																											
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																											
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																											
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																											
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																											
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																											
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																											
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																											
Y	2011	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2011	ALL	Chassis	Electronic Suspension Control																																																											
Y	2011	ALL	Body	Body Control Module																																																										
Y	2011	ALL	Body	CD Changer																																																										
Y	2011	ALL	Body	Digital Radio Receiver																																																										
Y	2011	ALL	Body	Driver Door Module																																																										
Y	2011	ALL	Body	Driver Door Switch																																																										
Y	2011	ALL	Body	Driver Position Module																																																										
Y	2011	ALL	Body	Folding Top Module																																																										
Y	2011	ALL	Body	Head Up Display																																																										
Y	2011	ALL	Body	HVAC Control Module																																																										
Y	2011	ALL	Body	Instrument Panel Cluster																																																										
Y	2011	ALL	Body	Navigation Radio																																																										
Y	2011	ALL	Body	Passenger Door Module																																																										
Y	2011	ALL	Body	Radio																																																										
Y	2011	ALL	Body	Personal Audio Link Module																																																										
Y	2011	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2011	ALL	Body	Steering Column Lock Module																																																										
Y	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																										
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																										
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																										
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																										
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																										
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																										
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																										
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																										
Y	2012	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2012	ALL	Chassis	Electronic Suspension Control																																																										
Y	2012	ALL	Body	Body Control Module																																																									
Y	2012	ALL	Body	CD Changer																																																									
Y	2012	ALL	Body	Digital Radio Receiver																																																									
Y	2012	ALL	Body	Driver Door Module																																																									
Y	2012	ALL	Body	Driver Door Switch																																																									
Y	2012	ALL	Body	Driver Position Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
Y	2012	ALL	Body	Folding Top Module																																																											
Y	2012	ALL	Body	Head Up Display																																																											
Y	2012	ALL	Body	HVAC Control Module																																																											
Y	2012	ALL	Body	Instrument Panel Cluster																																																											
Y	2012	ALL	Body	Navigation Radio																																																											
Y	2012	ALL	Body	Passenger Door Module																																																											
Y	2012	ALL	Body	Radio																																																											
Y	2012	ALL	Body	Personal Audio Link Module																																																											
Y	2012	ALL	Body	Remote Control Door Lock Receiver																																																											
Y	2012	ALL	Body	Steering Column Lock Module																																																											
Y	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																											
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																											
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																											
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																											
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																											
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																											
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																											
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																											
Y	2013	ALL	Chassis	Electronic Brake Control Module																																																											
Y	2013	ALL	Chassis	Electronic Suspension Control																																																											
Y	2013	ALL	Body	Body Control Module																																																										
Y	2013	ALL	Body	CD Changer																																																										
Y	2013	ALL	Body	Digital Radio Receiver																																																										
Y	2013	ALL	Body	Driver Door Module																																																										
Y	2013	ALL	Body	Driver Door Switch																																																										
Y	2013	ALL	Body	Driver Position Module																																																										
Y	2013	ALL	Body	Folding Top Module																																																										
Y	2013	ALL	Body	Head Up Display																																																										
Y	2013	ALL	Body	HVAC Control Module																																																										
Y	2013	ALL	Body	Instrument Panel Cluster																																																										
Y	2013	ALL	Body	Navigation Radio																																																										
Y	2013	ALL	Body	Passenger Door Module																																																										
Y	2013	ALL	Body	Radio																																																										
Y	2013	ALL	Body	Personal Audio Link Module																																																										
Y	2013	ALL	Body	Remote Control Door Lock Receiver																																																										
Y	2013	ALL	Body	Steering Column Lock Module																																																										
Y	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																										
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																										
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																										
Y	2014	Corvette	Powertrain	Chassis Control Module																																																										
Y	2014	Corvette	Chassis	Electronic Brake Control Module																																																										
Y	2014	Corvette	Chassis	Parking Brake Control Module																																																										
Y	2014	Corvette	Chassis	Power Steering Control Module																																																										
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																										
Y	2014	Corvette	Chassis	Suspension Control Module																																																										
Y	2014	Corvette	Body	Body Control Module Convertible																																																										
Y	2014	Corvette	Body	Body Control Module Coupe																																																										
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Y	2014	Corvette	Body	Passenger Presence Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
Y	2014	Corvette	Body	Instrument Cluster																																									V														
Y	2014	Corvette	Body	Radio/HVAC Control																																																						
Y	2014	Corvette	Body	Inside Rearview Mirror																																																						
Y	2014	Corvette	Body	Radio																																																						
Y	2014	Corvette	Body	Amplifier																																																						
Y	2014	Corvette	Body	Human Machine Interface Control Module																																																						
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																						
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																						
Y	2014	Corvette	Body	HVAC Control Module																																																						
Y	2014	Corvette	Body	Seat Memory Control Module - Passenger																																																						
Y	2014	Corvette	Body	Seat Memory Control Module - Driver																																																						
Y	2014	Corvette	Body	Folding Top Control Module																																																						
Y	2014	Corvette	Body	Keyless Entry Control Module																																																						
Y	2014	Corvette	Body	Steering Column Lock Control Module																																																						
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																						
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																						
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																						
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Automatic Transmission																																																						
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Manual Transmission																																																						
Y	2015	Corvette	Powertrain	6.2L LT4 Transmission Control Module																																																						
Y	2015	Corvette	Powertrain	Chassis Control Module																																																						
Y	2015	Corvette	Chassis	Electronic Brake Control Module																																																						
Y	2015	Corvette	Chassis	Parking Brake Control Module																																																						
Y	2015	Corvette	Chassis	Power Steering Control Module																																																						
Y	2015	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																						
Y	2015	Corvette	Chassis	Suspension Control Module																																																						
Y	2015	Corvette	Body	Body Control Module Convertible																																																						
Y	2015	Corvette	Body	Body Control Module Coupe																																																						
Y	2015	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
Y	2015	Corvette	Body	Passenger Presence Module																																																						
Y	2015	Corvette	Body	Instrument Cluster																																									V													
Y	2015	Corvette	Body	Radio/HVAC Control																																																						
Y	2015	Corvette	Body	Vehicle Performance Data Recorder																																																						
Y	2015	Corvette	Body	Inside Rearview Mirror																																																						
Y	2015	Corvette	Body	Radio																																																						
Y	2015	Corvette	Body	Amplifier																																																						
Y	2015	Corvette	Body	Human Machine Interface Control Module																																																						
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																						
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																						
Y	2015	Corvette	Body	HVAC Control Module																																																						
Y	2015	Corvette	Body	Seat Memory Control Module - Passenger																																																						
Y	2015	Corvette	Body	Seat Memory Control Module - Driver																																																						
Y	2015	Corvette	Body	Folding Top Control Module																																																						
Y	2015	Corvette	Body	Keyless Entry Control Module																																																						
Y	2015	Corvette	Body	Steering Column Lock Control Module																																																						
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																						
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																						
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Automatic Transmission																																																						
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Manual Transmission																																																						
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
Y	2016	Corvette	Powertrain	Rear Differential Clutch Control Module																																																											
Y	2016	Corvette	Chassis	Electronic Brake Control Module																																																												
Y	2016	Corvette	Chassis	Parking Brake Control Module																																																												
Y	2016	Corvette	Chassis	Power Steering Control Module																																																												
Y	2016	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																												
Y	2016	Corvette	Chassis	Suspension Control Module																																																												
Y	2016	Corvette	Body	Body Control Module																																																												
Y	2016	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
Y	2016	Corvette	Body	Passenger Presence Module																																																												
Y	2016	Corvette	Body	Instrument Cluster																																										V																	
Y	2016	Corvette	Body	Radio/HVAC Control																																																											
Y	2016	Corvette	Body	Vehicle Performance Data Recorder																																																												
Y	2016	Corvette	Body	Video Processing Control Module																																																												
Y	2016	Corvette	Body	Inside Rearview Mirror																																																												
Y	2016	Corvette	Body	Radio																																																												
Y	2016	Corvette	Body	Amplifier																																																												
Y	2016	Corvette	Body	Human Machine Interface Control Module																																																												
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																												
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																												
Y	2016	Corvette	Body	HVAC Control Module																																																												
Y	2016	Corvette	Body	Liftgate Control Module																																																												
Y	2016	Corvette	Body	Seat Memory Control Module - Passenger																																																												
Y	2016	Corvette	Body	Seat Memory Control Module - Driver																																																												
Y	2016	Corvette	Body	Folding Top Control Module																																																												
Y	2016	Corvette	Body	Keyless Entry Control Module																																																												
Y	2016	Corvette	Body	Steering Column Lock Control Module																																																												
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																												
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																												
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																												
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																												
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																												
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																												
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																												
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																												
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																												
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																												
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																												
Y	2016	Cruze	Chassis	Electronic Brake Control Module																																																												
Y	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																												
Y	2016	Cruze	Chassis	Power Steering Control Module																																																												
Y	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																												
Y	2016	Cruze	Body	Body Control Module																																																												
Y	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
Y	2016	Cruze	Body	Passenger Presence Module																																																												
Y	2016	Cruze	Body	Instrument Cluster																																																												
Y	2016	Cruze	Body	Radio Controls																																																												
Y	2016	Cruze	Body	HVAC Controls																																																												
Y	2016	Cruze	Body	Trailer Interface Control Module																																																												
Y	2016	Cruze	Body	Radio Base (IO3 IO7)																																																												
Y	2016	Cruze	Body	Radio (IOA)																																																												
Y	2016	Cruze	Body	Radio (IOB)																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
Y	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																								
Y	2016	Cruze	Body	Amplifier																																																								
Y	2016	Cruze	Body	Multimedia Player Interface Module																																																								
Y	2016	Cruze	Body	Human Machine Interface Control Module																																																								
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																								
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
Y	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
Y	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																								
Y	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																								
Y	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																								
Y	2016	Cruze	Body	Keyless Entry Control Module																																																								
Y	2016	Cruze	Body	Right Side Object Detection Control Module																																																								
Y	2016	Cruze	Body	Left Side Object Detection Control Module																																																								
Y	2016	Cruze	Body	Parking Assist Control Module																																																								
Y	2016	Cruze	Body	Frontview Camera Module																																																								
Y	2016	Cruze	Body	Steering Column Lock Control Module																																																								
Y	2016	Cruze	Body	Long Range Radar Sensor Module																																																								
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																									V															
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Transmission Control Module																																																								
Z	2004	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2004	ALL	Chassis	Power Steering Control Module																																																								
Z	2004	ALL	Body	Body Control Module																																																								
Z	2004	ALL	Body	Digital Radio Receiver																																																								
Z	2004	ALL	Body	HVAC Control Module																																																								
Z	2004	ALL	Body	Instrument Panel Cluster																																																								
Z	2004	ALL	Body	Radio																																																								
Z	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2004	ALL	Body	Theft Deterrent Module																																																								
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
Z	2005	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																									V															
Z	2005	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2005	ALL	Chassis	Power Steering Control Module																																																								
Z	2005	ALL	Body	Body Control Module																																																								
Z	2005	ALL	Body	Digital Radio Receiver																																																								
Z	2005	ALL	Body	HVAC Control Module																																																								
Z	2005	ALL	Body	Instrument Panel Cluster																																																								
Z	2005	ALL	Body	Radio																																																								
Z	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2005	ALL	Body	Theft Deterrent Module																																																								
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
Z	2006	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																									V															
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
Z	2006	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2006	ALL	Chassis	Power Steering Control Module																																																								
Z	2006	ALL	Body	Body Control Module																																																								
Z	2006	ALL	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
Z	2006	ALL	Body	HVAC Control Module																																																											
Z	2006	ALL	Body	Instrument Panel Cluster																																																											
Z	2006	ALL	Body	Radio																																																										
Z	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2006	ALL	Body	Theft Deterrent Module																																																										
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																										
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
Z	2007	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2007	ALL	Chassis	Power Steering Control Module																																																										
Z	2007	ALL	Body	Body Control Module																																																										
Z	2007	ALL	Body	Digital Radio Receiver																																																										
Z	2007	ALL	Body	Disc Player and Video Display																																																										
Z	2007	ALL	Body	HVAC Control Module																																																										
Z	2007	ALL	Body	Instrument Panel Cluster																																																										
Z	2007	ALL	Body	Radio																																																										
Z	2007	ALL	Body	Remote Control Door Lock Receiver																																																										
Z	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2007	ALL	Body	Theft Deterrent Module																																																										
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																										
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																										
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																										
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																										V	V																														
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																										
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																										
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																										
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
Z	2008	ALL	Chassis	Electronic Brake Control Module																																																										
Z	2008	ALL	Chassis	Power Steering Control Module																																																										
Z	2008	ALL	Body	Body Control Module Classic																																																										
Z	2008	ALL	Body	Body Control Module Malibu																																																										
Z	2008	ALL	Body	Digital Radio Receiver																																																										
Z	2008	ALL	Body	Disc Player and Video Display																																																										
Z	2008	ALL	Body	HVAC Control Module Classic																																																										
Z	2008	ALL	Body	HVAC Control Module Malibu																																																										
Z	2008	ALL	Body	Instrument Panel Cluster Classic																																																										
Z	2008	ALL	Body	Instrument Panel Cluster Malibu																																																										
Z	2008	ALL	Body	Radio																																																										
Z	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
Z	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
Z	2008	ALL	Body	Theft Deterrent Module																																																										
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																										
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																										V	V																														
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																										
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump																																																										
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump																																																										
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Without Tap Shift																																																												
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																													
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																													
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
Z	2009	ALL	Chassis	Electronic Brake Control Module																																																													
Z	2009	ALL	Chassis	Power Steering Control Module																																																													
Z	2009	ALL	Body	Body Control Module																																																													
Z	2009	ALL	Body	Digital Radio Receiver																																																													
Z	2009	ALL	Body	Disc Player and Video Display																																																													
Z	2009	ALL	Body	HVAC Control Module																																																													
Z	2009	ALL	Body	Instrument Panel Cluster																																																													
Z	2009	ALL	Body	Personal Audio Link Module																																																													
Z	2009	ALL	Body	Radio																																																													
Z	2009	ALL	Body	Supplemental Inflatable Restraint																																																													
Z	2009	ALL	Body	Theft Deterrent Module																																																													
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																													
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																											V	V																																
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																													
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Engine Control Module																																																													
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 6 Speed																											V	V																																
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 4 Speed																																																													
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																													
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																													
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																													
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																													
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
Z	2010	ALL	Chassis	Electronic Brake Control Module																																																													
Z	2010	ALL	Chassis	Power Steering Control Module																																																													
Z	2010	ALL	Body	Body Control Module																																																													
Z	2010	ALL	Body	Digital Radio Receiver																																																													
Z	2010	ALL	Body	HVAC Control Module																																																													
Z	2010	ALL	Body	Instrument Panel Cluster																																																													
Z	2010	ALL	Body	Personal Audio Link Module																																																													
Z	2010	ALL	Body	Radio																																																													
Z	2010	ALL	Body	Supplemental Inflatable Restraint																																																													
Z	2010	ALL	Body	Theft Deterrent Module																																																													
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																													
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																											V	V																																
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																													
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																											V	V																																
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
Z	2011	ALL	Chassis	Electronic Brake Control Module																																																													
Z	2011	ALL	Chassis	Power Steering Control Module																																																													
Z	2011	ALL	Body	Body Control Module																																																													
Z	2011	ALL	Body	Digital Radio Receiver																																																													
Z	2011	ALL	Body	HVAC Control Module																																																													
Z	2011	ALL	Body	Instrument Panel Cluster																																																													
Z	2011	ALL	Body	Personal Audio Link Module																																																													

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
Z	2011	ALL	Body	Radio																																																											
Z	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
Z	2011	ALL	Body	Theft Deterrent Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Engine Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Transmission Control Module																											V	V																															
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																											V	V																															
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																											V	V																															
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Chassis	Electronic Brake Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Chassis	Power Steering Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Body	Body Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Body	Digital Radio Receiver																																																											
Z	2012	Malibu (Seventh Gen)	Body	HVAC Control Module																																																											
Z	2012	Malibu (Seventh Gen)	Body	Instrument Panel Cluster																																																											
Z	2012	Malibu (Seventh Gen)	Body	Personal Audio Link Module																																																											
Z	2012	Malibu (Seventh Gen)	Body	Radio																																																											
Z	2012	Malibu (Seventh Gen)	Body	Supplemental Inflatable Restraint																																																											
Z	2012	Malibu (Seventh Gen)	Body	Theft Deterrent Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Fuel Pump Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Fuel Pump Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Powertrain	Rear Differential Clutch Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Electronic Brake Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Parking Brake Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Power Steering Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Steering Wheel Angle Sensor Module																																																											
Z	2012	Malibu (Eighth Gen)	Chassis	Suspension Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																											
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																											
Z	2012	Malibu (Eighth Gen)	Body	Passenger Presence Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
Z	2012	Malibu (Eighth Gen)	Body	Instrument Cluster																																																											
Z	2012	Malibu (Eighth Gen)	Body	Head-Up Display Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Headlamp Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Radio																																																											
Z	2012	Malibu (Eighth Gen)	Body	Digital Radio Receiver Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Multimedia Player Interface Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Mobile Telephone Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Dual (CJ2)																																																											
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Single (C68)																																																											
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Manual Single (C67)																																																											
Z	2012	Malibu (Eighth Gen)	Body	Rear Seat Heating Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Keyless Entry Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Right Side Object Detection Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Left Side Object Detection Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Parking Assist Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Vehicle Direction Camera Control Module																																																											
Z	2012	Malibu (Eighth Gen)	Body	Steering Column Lock Control Module																																																											
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Engine Control Module																																																											
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Transmission Control Module																																																											
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Engine Control Module																																																											
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 1																																																											
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 2																																																											
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module																																																											
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 6 Speed (MNM)																																																											
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 8 Speed (MRC)																																																											
Z	2016	Malibu	Chassis	Electronic Brake Control Module																																																											
Z	2016	Malibu	Chassis	Brake Booster Control Module																																																											
Z	2016	Malibu	Chassis	Power Steering Control Module																																																											
Z	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
Z	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
Z	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
Z	2016	Malibu	Body	Passenger Presence Module																																																											
Z	2016	Malibu	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
Z	2016	Malibu	Body	Instrument Cluster Enhanced Monochrome Driver Info Center (UDC)																																																											
Z	2016	Malibu	Body	Radio Controls																																																											
Z	2016	Malibu	Body	HVAC Controls																																																											
Z	2016	Malibu	Body	Active Safety Control Module																																																											
Z	2016	Malibu	Body	Headlamp Control Module																																																											
Z	2016	Malibu	Body	Radio Base																																																											
Z	2016	Malibu	Body	Radio (IOA)																																																											
Z	2016	Malibu	Body	Radio Uplevel (IO4 IO5 IO6)																																																											
Z	2016	Malibu	Body	Amplifier																																																											
Z	2016	Malibu	Body	Human Machine Interface Control Module																																																											
Z	2016	Malibu	Body	Navigation Control Module																																																											
Z	2016	Malibu	Body	Mobile Telephone Control Module																																																											
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																											
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																											
Z	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
Z	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											
Z	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																											
Z	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
Z	2016	Malibu	Body	Electric A/C Compressor Control Module																																																												
Z	2016	Malibu	Body	Seat Memory Control Module - Driver																																																												
Z	2016	Malibu	Body	Keyless Entry Control Module																																																												
Z	2016	Malibu	Body	Right Side Object Detection Control Module																																																												
Z	2016	Malibu	Body	Left Side Object Detection Control Module																																																												
Z	2016	Malibu	Body	Parking Assist Control Module																																																												
Z	2016	Malibu	Body	Frontview Camera Module																																																												
Z	2016	Malibu	Body	Frontview Camera Module																																																												
Z	2016	Malibu	Body	Steering Column Lock Control Module																																																												
Z	2016	Malibu	Body	Long Range Radar Sensor Module																																																												
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
1	2013	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																												
1	2013	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																												
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																												
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																												
1	2013	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																												
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Automatic Transmission																																																												
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Manual Transmission																																																												
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																												
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																												
1	2013	Malibu	Powertrain	2.0L LTD Fuel Pump Control Module																																																												
1	2013	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																												
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																												
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																												
1	2013	Malibu	Powertrain	(X) 2.0L LTG Fuel Pump Control Module																																																												
1	2013	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
1	2013	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																												
1	2013	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																												
1	2013	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																												
1	2013	Malibu	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																												
1	2013	Malibu	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																																																												
1	2013	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																												
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
1	2013	Malibu	Powertrain	(A) 2.5L LCV Fuel Pump Control Module																																																												
1	2013	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
1	2013	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
1	2013	Malibu	Chassis	Electronic Brake Control Module																																																												
1	2013	Malibu	Chassis	Parking Brake Control Module																																																												
1	2013	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2013	Malibu	Chassis	Power Steering Control Module																																																												
1	2013	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2013	Malibu	Chassis	Suspension Control Module																																																												
1	2013	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
1	2013	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																										
1	2013	Malibu	Body	Passenger Presence Module																																																											
1	2013	Malibu	Body	Instrument Cluster																																																											
1	2013	Malibu	Body	Headlamp Control Module																																																											
1	2013	Malibu	Body	Radio																																																											
1	2013	Malibu	Body	Digital Radio Receiver Control Module																																																											
1	2013	Malibu	Body	Multimedia Player Interface Module																																																											
1	2013	Malibu	Body	Mobile Telephone Control Module																																																											
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2013	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
1	2013	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											
1	2013	Malibu	Body	HVAC Control Module Manual Single (C67)																																																											
1	2013	Malibu	Body	Rear Seat Heating Control Module																																																											
1	2013	Malibu	Body	Keyless Entry Control Module																																																											
1	2013	Malibu	Body	Parking Assist Control Module																																																											
1	2013	Malibu	Body	Vehicle Direction Camera Control Module																																																											
1	2013	Malibu	Body	Steering Column Lock Control Module																																																											
1	2013	Malibu	Body	Battery Energy Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2014	Impala	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																											
1	2014	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																											
1	2014	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
1	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																											
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																											
1	2014	Impala	Chassis	Electronic Brake Control Module																																																											
1	2014	Impala	Chassis	Distance Sensing Cruise Control Module																																																											
1	2014	Impala	Chassis	Parking Brake Control Module																																																											
1	2014	Impala	Chassis	Power Steering Control Module																																																											
1	2014	Impala	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2014	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	Impala	Body	Passenger Presence Module																																																											
1	2014	Impala	Body	Instrument Cluster																																										V																
1	2014	Impala	Body	Radio Control																																																										
1	2014	Impala	Body	HVAC Control																																																										
1	2014	Impala	Body	Radio																																																										
1	2014	Impala	Body	Amplifier																																																										
1	2014	Impala	Body	Human Machine Interface Control Module																																																											
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Impala	Body	HVAC Control Module																																																											
1	2014	Impala	Body	Keyless Entry Control Module																																																											
1	2014	Impala	Body	Right Side Object Detection Control Module																																																											
1	2014	Impala	Body	Left Side Object Detection Control Module																																																											
1	2014	Impala	Body	Parking Assist Control Module																																																											
1	2014	Impala	Body	Frontview Camera Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2014	Impala	Body	Steering Column Lock Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																											
1	2014	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																											
1	2014	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																											
1	2014	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
1	2014	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
1	2014	Malibu	Chassis	Electronic Brake Control Module																																																											
1	2014	Malibu	Chassis	Parking Brake Control Module																																																											
1	2014	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2014	Malibu	Chassis	Power Steering Control Module																																																											
1	2014	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Malibu	Chassis	Suspension Control Module																																																											
1	2014	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2014	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																											
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																											
1	2014	Malibu	Body	Passenger Presence Module																																																											
1	2014	Malibu	Body	Instrument Cluster																																																											
1	2014	Malibu	Body	Headlamp Control Module																																																											
1	2014	Malibu	Body	Radio																																																										
1	2014	Malibu	Body	Digital Radio Receiver Control Module																																																											
1	2014	Malibu	Body	Multimedia Player Interface Module																																																											
1	2014	Malibu	Body	Mobile Telephone Control Module																																																											
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																											
1	2014	Malibu	Body	HVAC Control Module Auto Single (C68)																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2014	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2014	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
1	2014	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2014	Malibu	Body	Keyless Entry Control Module																																																										
1	2014	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2014	Malibu	Body	Parking Assist Control Module																																																										
1	2014	Malibu	Body	Frontview Camera Module																																																										
1	2014	Malibu	Body	Steering Column Lock Control Module																																																										
1	2015	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																										
1	2015	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																										
1	2015	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																										
1	2015	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																										
1	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																										
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																										
1	2015	Impala	Chassis	Electronic Brake Control Module																																																										
1	2015	Impala	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Impala	Chassis	Parking Brake Control Module																																																										
1	2015	Impala	Chassis	Power Steering Control Module																																																										
1	2015	Impala	Chassis	Power Steering Control Module																																																										
1	2015	Impala	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2015	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Impala	Body	Passenger Presence Module																																																										
1	2015	Impala	Body	Instrument Cluster																																										V																
1	2015	Impala	Body	Radio Control																																																									
1	2015	Impala	Body	HVAC Control																																																									
1	2015	Impala	Body	Radio																																																									
1	2015	Impala	Body	Amplifier																																																									
1	2015	Impala	Body	Human Machine Interface Control Module																																																										
1	2015	Impala	Body	Telematics Communication Interface Control Module																																																										
1	2015	Impala	Body	HVAC Control Module																																																										
1	2015	Impala	Body	Keyless Entry Control Module																																																										
1	2015	Impala	Body	Right Side Object Detection Control Module																																																										
1	2015	Impala	Body	Left Side Object Detection Control Module																																																										
1	2015	Impala	Body	Parking Assist Control Module																																																										
1	2015	Impala	Body	Frontview Camera Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Chassis Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LBS Chassis Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																										
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
1	2015	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2015	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																									
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																									
1	2015	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																									
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	2.4L LE9 Chassis Control Module																																																									
1	2015	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																									
1	2015	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																									
1	2015	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																									
1	2015	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																									
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																									
1	2015	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																									
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	3.0L LFW Chassis Control Module																																																									
1	2015	Malibu	Powertrain	3.0L LFW Transmission Control Module																																																									
1	2015	Malibu	Powertrain	Rear Differential Clutch Control Module																																																									
1	2015	Malibu	Chassis	Electronic Brake Control Module																																																									
1	2015	Malibu	Chassis	Parking Brake Control Module																																																									
1	2015	Malibu	Chassis	Power Steering Control Module																																																									
1	2015	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2015	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
1	2015	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
1	2015	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2015	Malibu	Body	Passenger Presence Module																																																									
1	2015	Malibu	Body	Instrument Cluster																																																									
1	2015	Malibu	Body	Headlamp Control Module																																																									
1	2015	Malibu	Body	Radio																																																									
1	2015	Malibu	Body	Digital Radio Receiver Control Module																																																									
1	2015	Malibu	Body	Multimedia Player Interface Module																																																									
1	2015	Malibu	Body	Mobile Telephone Control Module																																																									
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																									
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2015	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																									
1	2015	Malibu	Body	HVAC Control Module Auto Single (C68)																																																									
1	2015	Malibu	Body	HVAC Control Module Manual Single (C67)																																																									
1	2015	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																									
1	2015	Malibu	Body	Front Seat Heating Control Module																																																									
1	2015	Malibu	Body	Rear Seat Heating Control Module																																																									
1	2015	Malibu	Body	Keyless Entry Control Module																																																									
1	2015	Malibu	Body	Left Side Object Detection Control Module																																																									
1	2015	Malibu	Body	Parking Assist Control Module																																																									
1	2015	Malibu	Body	Frontview Camera Module																																																									
1	2015	Malibu	Body	Steering Column Lock Control Module																																																									
1	2015	Malibu (LSG)	Powertrain	1.6L LLU Engine Control Module																																																									
1	2015	Malibu (LSG)	Powertrain	Transmission Control Module																																																									
1	2015	Malibu (LSG)	Powertrain	Rear Differential Clutch Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2015	Malibu (LSG)	Chassis	Electronic Brake Control Module																																																										
1	2015	Malibu (LSG)	Chassis	Parking Brake Control Module																																																										
1	2015	Malibu (LSG)	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Malibu (LSG)	Chassis	Suspension Control Module																																																										
1	2015	Malibu (LSG)	Body	Body Control Module																																																										
1	2015	Malibu (LSG)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Malibu (LSG)	Body	Instrument Cluster																																																										
1	2015	Malibu (LSG)	Body	Headlamp Control Module																																																										
1	2015	Malibu (LSG)	Body	Radio																																																										
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Malibu (LSG)	Body	HVAC Control Module																																																										
1	2015	Malibu (LSG)	Body	Front Seat Heating Control Module																																																										
1	2015	Malibu (LSG)	Body	Keyless Entry Control Module																																																										
1	2015	Malibu (LSG)	Body	Left Side Object Detection Control Module																																																										
1	2015	Malibu (LSG)	Body	Parking Assist Control Module																																																										
1	2015	Malibu (LSG)	Body	Frontview Camera Module																																																										
1	2015	Malibu (LSG)	Body	Steering Column Lock Control Module																																																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
1	2016	Impala	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2016	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																										
1	2016	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																										
1	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
1	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
1	2016	Impala	Powertrain	Chassis Control Module																																																										
1	2016	Impala	Chassis	Electronic Brake Control Module																																																										
1	2016	Impala	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Impala	Chassis	Parking Brake Control Module																																																										
1	2016	Impala	Chassis	Power Steering Control Module																																																										
1	2016	Impala	Chassis	Power Steering Control Module																																																										
1	2016	Impala	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2016	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Impala	Body	Passenger Presence Module																																																										
1	2016	Impala	Body	Instrument Cluster																																										V																
1	2016	Impala	Body	Radio Control																																																									
1	2016	Impala	Body	HVAC Control																																																									
1	2016	Impala	Body	Radio																																																									
1	2016	Impala	Body	Amplifier																																																									
1	2016	Impala	Body	Human Machine Interface Control Module																																																										
1	2016	Impala	Body	Navigation Control Module																																																										
1	2016	Impala	Body	Telematics Communication Interface Control Module																																																										
1	2016	Impala	Body	HVAC Control Module																																																										
1	2016	Impala	Body	Seat Memory Control Module - Driver																																																										
1	2016	Impala	Body	Keyless Entry Control Module																																																										
1	2016	Impala	Body	Right Side Object Detection Control Module																																																										
1	2016	Impala	Body	Left Side Object Detection Control Module																																																										
1	2016	Impala	Body	Parking Assist Control Module																																																										
1	2016	Impala	Body	Frontview Camera Module																																																										
1	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																											
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
1	2016	Malibu	Powertrain	Fuel Injector Control Module																																																											
1	2016	Malibu	Powertrain	Chassis Control Module																																																											
1	2016	Malibu	Chassis	Electronic Brake Control Module																																																											
1	2016	Malibu	Chassis	Parking Brake Control Module																																																											
1	2016	Malibu	Chassis	Power Steering Control Module																																																											
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2016	Malibu	Body	Passenger Presence Module																																																											
1	2016	Malibu	Body	Instrument Cluster																																																											
1	2016	Malibu	Body	Headlamp Control Module																																																											
1	2016	Malibu	Body	Radio																																																										
1	2016	Malibu	Body	Digital Radio Receiver Control Module																																																										
1	2016	Malibu	Body	Multimedia Player Interface Module																																																										
1	2016	Malibu	Body	Mobile Telephone Control Module																																																										
1	2016	Malibu	Body	Telematics Communication Interface Control Module																																																										
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
1	2016	Malibu	Body	Seat Memory Control Module																																																										
1	2016	Malibu	Body	Front Seat Heating Control Module																																																										
1	2016	Malibu	Body	Rear Seat Heating Control Module																																																										
1	2016	Malibu	Body	Keyless Entry Control Module																																																										
1	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
1	2016	Malibu	Body	Parking Assist Control Module																																																										
1	2016	Malibu	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2005	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																								
A	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
A	2005	ALL	Powertrain	Transmission Control Module																																																								
A	2005	ALL	Chassis	Power Steering Control Module																																																								
A	2005	ALL	Chassis	Anti-lock Brake System																																																								
A	2005	ALL	Body	Body Control Module																																																								
A	2005	ALL	Body	Digital Radio Receiver																																																								
A	2005	ALL	Body	Instrument Panel																																																								
A	2005	ALL	Body	Radio																																																								
A	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
A	2006	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																								
A	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
A	2006	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																								
A	2006	ALL	Powertrain	Transmission Control Module																																																								
A	2006	ALL	Chassis	Power Steering Control Module																																																								
A	2006	ALL	Chassis	Anti-lock Brake System																																																								
A	2006	ALL	Body	Body Control Module																																																								
A	2006	ALL	Body	Digital Radio Receiver																																																								
A	2006	ALL	Body	Instrument Panel																																																								
A	2006	ALL	Body	Radio																																																								
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
A	2006	ALL	Body	Theft Deterrent Module																																																								
A	2007	ALL	Powertrain	(P)2.0L L4 LSJ Engine Control Module																																																								
A	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
A	2007	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																								
A	2007	ALL	Powertrain	Transmission Control Module																																																								
A	2007	ALL	Chassis	Power Steering Control Module																																																								
A	2007	ALL	Chassis	Electronic Brake Control Module																																																								
A	2007	ALL	Body	Body Control Module																																																								
A	2007	ALL	Body	Digital Radio Receiver																																																								
A	2007	ALL	Body	Instrument Panel Cluster																																																								
A	2007	ALL	Body	Passenger Presence System																																																								
A	2007	ALL	Body	Personal Audio Link Module																																																								
A	2007	ALL	Body	Radio																																																								
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
A	2007	ALL	Body	Theft Deterrent Module																																																								
A	2008	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																								
A	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
A	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																								
A	2008	ALL	Powertrain	Transmission Control Module																																																								
A	2008	ALL	Chassis	Power Steering Control Module																																																								
A	2008	ALL	Chassis	Electronic Brake Control Module with VSES																																																								
A	2008	ALL	Chassis	Electronic Brake Control Module without VSES																																																								
A	2008	ALL	Body	Body Control Module																																																								
A	2008	ALL	Body	Digital Radio Receiver																																																								
A	2008	ALL	Body	Instrument Panel Cluster																																																								
A	2008	ALL	Body	Passenger Presence System																																																								
A	2008	ALL	Body	Personal Audio Link Module																																																								
A	2008	ALL	Body	Radio																																																								
A	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
A	2008	ALL	Body	Theft Deterrent Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2009	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																									
A	2009	ALL	Powertrain	(H)2.2L L4 LAP Engine Control Module																																																									
A	2009	ALL	Powertrain	Transmission Control Module																																																									
A	2009	ALL	Chassis	Power Steering Control Module																																																									
A	2009	ALL	Chassis	Electronic Brake Control Module with VSES																																																									
A	2009	ALL	Chassis	Electronic Brake Control Module without VSES																																																									
A	2009	ALL	Body	Body Control Module																																																									
A	2009	ALL	Body	Digital Radio Receiver																																																									
A	2009	ALL	Body	Instrument Panel Cluster																																																									
A	2009	ALL	Body	Passenger Presence System																																																									
A	2009	ALL	Body	Personal Audio Link Module																																																									
A	2009	ALL	Body	Radio																																																									
A	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2009	ALL	Body	Theft Deterrent Module																																																									
A	2010	ALL	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																									
A	2010	ALL	Powertrain	(5)2.2L L4 LAP Engine Control Module																																																									
A	2010	ALL	Powertrain	Transmission Control Module																																																									
A	2010	ALL	Chassis	Power Steering Control Module																																																									
A	2010	ALL	Chassis	Electronic Brake Control Module with VSES																																																									
A	2010	ALL	Chassis	Electronic Brake Control Module without VSES																																																									
A	2010	ALL	Body	Body Control Module																																																									
A	2010	ALL	Body	Digital Radio Receiver																																																									
A	2010	ALL	Body	Driver Information Center																																																									
A	2010	ALL	Body	Instrument Panel Cluster																																																									
A	2010	ALL	Body	Passenger Presence System																																																									
A	2010	ALL	Body	Personal Audio Link Module																																																									
A	2010	ALL	Body	Radio																																																									
A	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2010	ALL	Body	Theft Deterrent Module																																																									
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
A	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
A	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																									
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
A	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
A	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																									
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																									
A	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																									
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
A	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
A	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
A	2012	Cobalt	Chassis	Electronic Brake Control Module																																																									
A	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																									
A	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2012	Cobalt	Body	Body Control Module																																																									
A	2012	Cobalt	Body	Passenger Presence Module																																																									
A	2012	Cobalt	Body	Instrument Cluster																																																									
A	2012	Cobalt	Body	Radio																																																									
A	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																									
A	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																									
A	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
A	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																								
A	2012	Cobalt	Body	Front Seat Heating Control Module																																																								
A	2012	Cobalt	Body	Parking Assist Control Module																																																								
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
A	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																								
A	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																								
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																								
A	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																								
A	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																								
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																								
A	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
A	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																								
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																								
A	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																								
A	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																								
A	2013	Cobalt	Chassis	Electronic Brake Control Module																																																								
A	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2013	Cobalt	Body	Body Control Module																																																								
A	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2013	Cobalt	Body	Instrument Cluster																																																								
A	2013	Cobalt	Body	Radio																																																								
A	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																								
A	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																								
A	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
A	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																								
A	2013	Cobalt	Body	Front Seat Heating Control Module																																																								
A	2013	Cobalt	Body	Parking Assist Control Module																																																								
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								
A	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																								
A	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																								
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																								
A	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																								
A	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																								
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																								
A	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
A	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																								
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																								
A	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																								
A	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																								
A	2014	Cobalt	Chassis	Electronic Brake Control Module																																																								
A	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2014	Cobalt	Body	Body Control Module																																																								
A	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2014	Cobalt	Body	Instrument Cluster																																																								
A	2014	Cobalt	Body	Radio																																																								
A	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
A	2014	Cobalt	Body	Front Seat Heating Control Module																																																									
A	2014	Cobalt	Body	Parking Assist Control Module																																																									
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
A	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																									
A	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																									
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																									
A	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																									
A	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																									
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
A	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
A	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																									
A	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																									
A	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																									
A	2015	Cobalt	Chassis	Electronic Brake Control Module																																																									
A	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2015	Cobalt	Body	Body Control Module																																																									
A	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2015	Cobalt	Body	Instrument Cluster																																																									
A	2015	Cobalt	Body	Radio																																																									
A	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																									
A	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									
A	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
A	2015	Cobalt	Body	Front Seat Heating Control Module																																																									
A	2015	Cobalt	Body	Parking Assist Control Module																																																									
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
A	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																									
A	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																									
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																									
A	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																									
A	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																									
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
A	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
A	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																									
A	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																									
A	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																									
A	2016	Cobalt	Chassis	Electronic Brake Control Module																																																									
A	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2016	Cobalt	Body	Body Control Module																																																									
A	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2016	Cobalt	Body	Instrument Cluster																																																									
A	2016	Cobalt	Body	Radio Other																																																									
A	2016	Cobalt	Body	Radio (IOB)																																																									
A	2016	Cobalt	Body	Radio (UF7)																																																									
A	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
A	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																								
A	2016	Cobalt	Body	Front Seat Heating Control Module																																																								
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																							
B	2010	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																							
B	2010	Beat	Powertrain	1.19L LC5 Engine Control Module																																																							
B	2010	Beat	Powertrain	Transmission Control Module																																																							
B	2010	Beat	Chassis	Electronic Brake Control Module																																																							
B	2010	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																							
B	2010	Beat	Chassis	Power Steering Control Module																																																							
B	2010	Beat	Chassis	Steering Wheel Angle Sensor Module																																																							
B	2010	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
B	2010	Beat	Body	Instrument Cluster																																																							
B	2010	Beat	Body	Keyless Entry Control Module																																																							
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Automatic Transmission																																																							
B	2011	Beat	Powertrain	1.0L LEB Engine Control Module Manual Transmission																																																							
B	2011	Beat	Powertrain	1.19L LC5 Engine Control Module																																																							
B	2011	Beat	Powertrain	Transmission Control Module																																																							
B	2011	Beat	Chassis	Electronic Brake Control Module																																																							
B	2011	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																							
B	2011	Beat	Chassis	Electric Power Steering Control Module																																																							
B	2011	Beat	Chassis	Steering Wheel Angle Sensor Module																																																							
B	2011	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
B	2011	Beat	Body	Instrument Cluster																																																						
B	2011	Beat	Body	Keyless Entry Control Module																																																						
B	2012	Beat	Powertrain	1.0L LEB Engine Control Module																																																						
B	2012	Beat	Powertrain	1.19L LC5 Engine Control Module																																																						
B	2012	Beat	Powertrain	Transmission Control Module																																																						
B	2012	Beat	Chassis	Electronic Brake Control Module																																																						
B	2012	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																						
B	2012	Beat	Chassis	Electric Power Steering Control Module																																																						
B	2012	Beat	Chassis	Steering Wheel Angle Sensor Module																																																						
B	2012	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
B	2012	Beat	Body	Instrument Cluster																																																						
B	2012	Beat	Body	Keyless Entry Control Module																																																						
B	2013	Beat	Powertrain	1.0L LEB Engine Control Module																																																						
B	2013	Beat	Powertrain	1.19L LC5 Engine Control Module																																																						
B	2013	Beat	Powertrain	Transmission Control Module																																																						
B	2013	Beat	Chassis	Electronic Brake Control Module																																																						
B	2013	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																						
B	2013	Beat	Chassis	Electric Power Steering Control Module																																																						
B	2013	Beat	Chassis	Steering Wheel Angle Sensor Module																																																						
B	2013	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
B	2013	Beat	Body	Instrument Cluster																																																						
B	2013	Beat	Body	Keyless Entry Control Module																																																						
B	2014	Beat	Powertrain	1.0L LEB Engine Control Module																																																						
B	2014	Beat	Powertrain	1.19L LC5 Engine Control Module																																																						
B	2014	Beat	Powertrain	Transmission Control Module																																																						
B	2014	Beat	Powertrain	Fuel Injector Control Module																																																						
B	2014	Beat	Chassis	Electronic Brake Control Module																																																						
B	2014	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																						

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
B	2014	Beat	Chassis	Power Steering Control Module																																																								
B	2014	Beat	Chassis	Steering Wheel Angle Sensor Module																																																								
B	2014	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
B	2014	Beat	Body	Instrument Cluster																																																								
B	2014	Beat	Body	Telematics Communication Interface Control Module																																																								
B	2015	Beat	Powertrain	1.0L LEB Engine Control Module																																																								
B	2015	Beat	Powertrain	1.19L LC5 Engine Control Module																																																								
B	2015	Beat	Powertrain	Transmission Control Module																																																								
B	2015	Beat	Powertrain	Fuel Injector Control Module																																																								
B	2015	Beat	Chassis	Electronic Brake Control Module																																																								
B	2015	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																								
B	2015	Beat	Chassis	Power Steering Control Module																																																								
B	2015	Beat	Chassis	Steering Wheel Angle Sensor Module																																																								
B	2015	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
B	2015	Beat	Body	Instrument Cluster																																																								
B	2015	Beat	Body	Radio																																																								
B	2015	Beat	Body	Telematics Communication Interface Control Module																																																								
B	2015	Beat	Body	Keyless Entry Control Module																																																								
B	2016	Beat	Powertrain	1.0L LEB Engine Control Module																																																								
B	2016	Beat	Powertrain	1.19L LC5 Engine Control Module																																																								
B	2016	Beat	Powertrain	Transmission Control Module																																																								
B	2016	Beat	Chassis	Electronic Brake Control Module																																																								
B	2016	Beat	Chassis	Multi-Axis Acceleration Sensor Module																																																								
B	2016	Beat	Chassis	Power Steering Control Module																																																								
B	2016	Beat	Chassis	Steering Wheel Angle Sensor Module																																																								
B	2016	Beat	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
B	2016	Beat	Body	Instrument Cluster																																																								
B	2016	Beat	Body	Radio																																																								
B	2016	Beat	Body	Telematics Communication Interface Control Module																																																								
B	2016	Beat	Body	HVAC Control Module																																																								
B	2016	Beat	Body	Keyless Entry Control Module																																																								
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																								
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																								
B	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																								
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																								
B	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																								
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																								
B	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																								
B	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																								
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																								
B	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																								
B	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																								
B	2016	Cruze	Chassis	Electronic Brake Control Module																																																								
B	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																								
B	2016	Cruze	Chassis	Power Steering Control Module																																																								
B	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
B	2016	Cruze	Body	Body Control Module																																																								
B	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
B	2016	Cruze	Body	Passenger Presence Module																																																								
B	2016	Cruze	Body	Instrument Cluster																																																								
B	2016	Cruze	Body	Radio Controls																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
B	2016	Cruze	Body	HVAC Controls																																																								
B	2016	Cruze	Body	Trailer Interface Control Module																																																								
B	2016	Cruze	Body	Radio Base (IO3 IO7)																																																								
B	2016	Cruze	Body	Radio (IOA)																																																								
B	2016	Cruze	Body	Radio (IOB)																																																								
B	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																								
B	2016	Cruze	Body	Amplifier																																																								
B	2016	Cruze	Body	Multimedia Player Interface Module																																																								
B	2016	Cruze	Body	Human Machine Interface Control Module																																																								
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																								
B	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
B	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
B	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																								
B	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																								
B	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																								
B	2016	Cruze	Body	Keyless Entry Control Module																																																								
B	2016	Cruze	Body	Right Side Object Detection Control Module																																																								
B	2016	Cruze	Body	Left Side Object Detection Control Module																																																								
B	2016	Cruze	Body	Parking Assist Control Module																																																								
B	2016	Cruze	Body	Frontview Camera Module																																																								
B	2016	Cruze	Body	Steering Column Lock Control Module																																																								
B	2016	Cruze	Body	Long Range Radar Sensor Module																																																								
C	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
C	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
C	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
C	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
C	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
C	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
C	2010	Spark	Powertrain	Transmission Control Module																																																								
C	2010	Spark	Chassis	Electronic Brake Control Module																																																								
C	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
C	2010	Spark	Chassis	Electric Power Steering Control Module																																																								
C	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2010	Spark	Body	Passenger Presence Module																																																								
C	2010	Spark	Body	Instrument Cluster																																																								
C	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
C	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
C	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
C	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
C	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																								
C	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																								
C	2011	Spark	Powertrain	Transmission Control Module																																																								
C	2011	Spark	Chassis	Electronic Brake Control Module																																																								
C	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
C	2011	Spark	Chassis	Electric Power Steering Control Module																																																								
C	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2011	Spark	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2011	Spark	Body	Instrument Cluster																																																								
C	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
C	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																									
C	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																									
C	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																									
C	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																									
C	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																									
C	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																									
C	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																									
C	2012	Spark	Powertrain	Transmission Control Module																																																									
C	2012	Spark	Chassis	Electronic Brake Control Module																																																									
C	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
C	2012	Spark	Chassis	Electric Power Steering Control Module																																																									
C	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2012	Spark	Body	Passenger Presence Module																																																									
C	2012	Spark	Body	Instrument Cluster																																																									
C	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
C	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																									
C	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																									
C	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																									
C	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																									
C	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																									
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																									
C	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																									
C	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																									
C	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																									
C	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																									
C	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																									
C	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																									
C	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
C	2013	Spark	Powertrain	Fuel Injector Control Module																																																									
C	2013	Spark	Chassis	Electronic Brake Control Module																																																									
C	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
C	2013	Spark	Chassis	Power Steering Control Module																																																									
C	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2013	Spark	Body	Body Control Module																																																									
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2013	Spark	Body	Passenger Presence Module																																																									
C	2013	Spark	Body	Instrument Cluster																																																									
C	2013	Spark	Body	Radio																																																									
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																									
C	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																									
C	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																									
C	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																									
C	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
C	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																								
C	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																								
C	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																								
C	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
C	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																								
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																								
C	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																								
C	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																								
C	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																								
C	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
C	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
C	2014	Spark	Powertrain	Fuel Injector Control Module																																																								
C	2014	Spark	Chassis	Electronic Brake Control Module																																																								
C	2014	Spark	Chassis	Electronic Brake Control Module																																																								
C	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
C	2014	Spark	Chassis	Power Steering Control Module																																																								
C	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2014	Spark	Body	Body Control Module																																																								
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Spark	Body	Passenger Presence Module																																																								
C	2014	Spark	Body	Instrument Cluster																																																								
C	2014	Spark	Body	Radio																																																								
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																								
C	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2014	Spark	Body	Keyless Entry Control Module																																																								
C	2014	Spark EV	Powertrain	Engine Control Module																																																								
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																								
C	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																								
C	2014	Spark EV	Powertrain	Drive Motor Control Module																																																								
C	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								
C	2014	Spark EV	Chassis	Electronic Brake Control Module																																																								
C	2014	Spark EV	Chassis	Parking Brake Control Module																																																								
C	2014	Spark EV	Chassis	Power Steering Control Module																																																								
C	2014	Spark EV	Body	Body Control Module																																																								
C	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
C	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Spark EV	Body	Passenger Presence Module																																																								
C	2014	Spark EV	Body	Instrument Cluster																																																								
C	2014	Spark EV	Body	Radio																																																								
C	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2014	Spark EV	Body	HVAC Control Module																																																								
C	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																								
C	2014	Spark EV	Body	Coolant Heater Control Module																																																								
C	2014	Spark EV	Body	Keyless Entry Control Module																																																								
C	2014	Spark EV	Body	Battery Charger Control Module																																																								
C	2014	Spark EV	Body	DC Charging Control Module																																																								
C	2014	Spark EV	Body	Battery Energy Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																									
C	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
C	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Spark	Chassis	Power Steering Control Module																																																										
C	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Spark	Body	Body Control Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark	Body	Passenger Presence Module																																																										
C	2015	Spark	Body	Instrument Cluster																																																										
C	2015	Spark	Body	Instrument Cluster																																																										
C	2015	Spark	Body	Tire Pressure Indicator Module																																																										
C	2015	Spark	Body	Radio																																																										
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Spark	Body	Keyless Entry Control Module																																																										
C	2015	Spark EV	Powertrain	Engine Control Module																																																										
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
C	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
C	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
C	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2015	Spark EV	Chassis	Electronic Brake Control Module																																																										
C	2015	Spark EV	Chassis	Parking Brake Control Module																																																										
C	2015	Spark EV	Chassis	Power Steering Control Module																																																										
C	2015	Spark EV	Body	Body Control Module																																																										
C	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
C	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Spark EV	Body	Passenger Presence Module																																																										
C	2015	Spark EV	Body	Instrument Cluster																																																										
C	2015	Spark EV	Body	Radio																																																										
C	2015	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																									
C	2015	Spark EV	Body	Coolant Heater Control Module																																																										
C	2015	Spark EV	Body	Keyless Entry Control Module																																																										
C	2015	Spark EV	Body	Battery Charger Control Module																																																										
C	2015	Spark EV	Body	DC Charging Control Module																																																										
C	2015	Spark EV	Body	Battery Energy Control Module																																																										
C	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
C	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																										
C	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
C	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																										
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																										
C	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																										
C	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
C	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
C	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																										
C	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																										
C	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																										
C	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
C	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																										
C	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																										
C	2016	Spark	Powertrain	Fuel Injector Control Module																																																										
C	2016	Spark	Chassis	Electronic Brake Control Module																																																										
C	2016	Spark	Chassis	Electronic Brake Control Module																																																										
C	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2016	Spark	Chassis	Power Steering Control Module																																																										
C	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Spark	Body	Body Control Module																																																									
C	2016	Spark	Body	Body Control Module																																																									
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Spark	Body	Instrument Cluster																																																									
C	2016	Spark	Body	Instrument Cluster																																																									
C	2016	Spark	Body	Radio																																																									
C	2016	Spark	Body	Telematics Communication Interface Control Module																																																									
C	2016	Spark	Body	Keyless Entry Control Module																																																									
C	2016	Spark EV	Powertrain	Engine Control Module																																																									
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																									
C	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																									
C	2016	Spark EV	Powertrain	Drive Motor Control Module																																																									
C	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																									
C	2016	Spark EV	Chassis	Electronic Brake Control Module																																																									
C	2016	Spark EV	Chassis	Parking Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2016	Spark EV	Chassis	Power Steering Control Module																																																								
C	2016	Spark EV	Body	Body Control Module																																																								
C	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
C	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2016	Spark EV	Body	Passenger Presence Module																																																								
C	2016	Spark EV	Body	Instrument Cluster																																																								
C	2016	Spark EV	Body	Radio																																																								
C	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																								
C	2016	Spark EV	Body	HVAC Control Module																																																								
C	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																								
C	2016	Spark EV	Body	Coolant Heater Control Module																																																								
C	2016	Spark EV	Body	Keyless Entry Control Module																																																								
C	2016	Spark EV	Body	Frontview Camera Module																																																								
C	2016	Spark EV	Body	Battery Charger Control Module																																																								
C	2016	Spark EV	Body	DC Charging Control Module																																																								
C	2016	Spark EV	Body	Battery Energy Control Module																																																								
D	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
D	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
D	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
D	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
D	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
D	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
D	2010	Spark	Powertrain	Transmission Control Module																																																								
D	2010	Spark	Chassis	Electronic Brake Control Module																																																								
D	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
D	2010	Spark	Chassis	Electric Power Steering Control Module																																																								
D	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2010	Spark	Body	Passenger Presence Module																																																								
D	2010	Spark	Body	Instrument Cluster																																																								
D	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
D	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
D	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
D	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
D	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																								
D	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																								
D	2011	Spark	Powertrain	Transmission Control Module																																																								
D	2011	Spark	Chassis	Electronic Brake Control Module																																																								
D	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
D	2011	Spark	Chassis	Electric Power Steering Control Module																																																								
D	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2011	Spark	Body	Passenger Presence Module																																																								
D	2011	Spark	Body	Instrument Cluster																																																								
D	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
D	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
D	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
D	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
D	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
D	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																								
D	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																									
D	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																									
D	2012	Spark	Powertrain	Transmission Control Module																																																									
D	2012	Spark	Chassis	Electronic Brake Control Module																																																									
D	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
D	2012	Spark	Chassis	Electric Power Steering Control Module																																																									
D	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2012	Spark	Body	Passenger Presence Module																																																									
D	2012	Spark	Body	Instrument Cluster																																																									
D	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
D	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																									
D	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																									
D	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																									
D	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																									
D	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																									
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																									
D	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																									
D	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																									
D	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																									
D	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																									
D	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																									
D	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																									
D	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																									
D	2013	Spark	Powertrain	Fuel Injector Control Module																																																									
D	2013	Spark	Chassis	Electronic Brake Control Module																																																									
D	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																									
D	2013	Spark	Chassis	Power Steering Control Module																																																									
D	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																									
D	2013	Spark	Body	Body Control Module																																																									
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
D	2013	Spark	Body	Passenger Presence Module																																																									
D	2013	Spark	Body	Instrument Cluster																																																									
D	2013	Spark	Body	Radio																																																									
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																									
D	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																									
D	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																									
D	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																									
D	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																									
D	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																									
D	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																									
D	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																									
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																									
D	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																									
D	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																									
D	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																									
D	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																									
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																								
D	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																								
D	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																								
D	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																								
D	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
D	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
D	2014	Spark	Powertrain	Fuel Injector Control Module																																																								
D	2014	Spark	Chassis	Electronic Brake Control Module																																																								
D	2014	Spark	Chassis	Electronic Brake Control Module																																																								
D	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
D	2014	Spark	Chassis	Power Steering Control Module																																																								
D	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
D	2014	Spark	Body	Body Control Module																																																								
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2014	Spark	Body	Passenger Presence Module																																																								
D	2014	Spark	Body	Instrument Cluster																																																								
D	2014	Spark	Body	Radio																																																								
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																								
D	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																								
D	2014	Spark	Body	Keyless Entry Control Module																																																								
D	2014	Spark EV	Powertrain	Engine Control Module																																																								
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																								
D	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																								
D	2014	Spark EV	Powertrain	Drive Motor Control Module																																																								
D	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								
D	2014	Spark EV	Chassis	Electronic Brake Control Module																																																								
D	2014	Spark EV	Chassis	Parking Brake Control Module																																																								
D	2014	Spark EV	Chassis	Power Steering Control Module																																																								
D	2014	Spark EV	Body	Body Control Module																																																								
D	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
D	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2014	Spark EV	Body	Passenger Presence Module																																																								
D	2014	Spark EV	Body	Instrument Cluster																																																								
D	2014	Spark EV	Body	Radio																																																								
D	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																								
D	2014	Spark EV	Body	HVAC Control Module																																																								
D	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																								
D	2014	Spark EV	Body	Coolant Heater Control Module																																																								
D	2014	Spark EV	Body	Keyless Entry Control Module																																																								
D	2014	Spark EV	Body	Battery Charger Control Module																																																								
D	2014	Spark EV	Body	DC Charging Control Module																																																								
D	2014	Spark EV	Body	Battery Energy Control Module																																																								
D	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																								
D	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																								
D	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																								
D	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
D	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																								
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
D	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																								
D	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																								
D	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
D	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																								
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																								
D	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																								
D	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																								
D	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																								
D	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
D	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
D	2015	Spark	Powertrain	Fuel Injector Control Module																																																								
D	2015	Spark	Chassis	Electronic Brake Control Module																																																								
D	2015	Spark	Chassis	Electronic Brake Control Module																																																								
D	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
D	2015	Spark	Chassis	Power Steering Control Module																																																								
D	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
D	2015	Spark	Body	Body Control Module																																																								
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2015	Spark	Body	Passenger Presence Module																																																								
D	2015	Spark	Body	Instrument Cluster																																																								
D	2015	Spark	Body	Instrument Cluster																																																								
D	2015	Spark	Body	Tire Pressure Indicator Module																																																								
D	2015	Spark	Body	Radio																																																								
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																								
D	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																								
D	2015	Spark	Body	Keyless Entry Control Module																																																								
D	2015	Spark EV	Powertrain	Engine Control Module																																																								
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																								
D	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																								
D	2015	Spark EV	Powertrain	Drive Motor Control Module																																																								
D	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								
D	2015	Spark EV	Chassis	Electronic Brake Control Module																																																								
D	2015	Spark EV	Chassis	Parking Brake Control Module																																																								
D	2015	Spark EV	Chassis	Power Steering Control Module																																																								
D	2015	Spark EV	Body	Body Control Module																																																								
D	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
D	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2015	Spark EV	Body	Passenger Presence Module																																																								
D	2015	Spark EV	Body	Instrument Cluster																																																								
D	2015	Spark EV	Body	Radio																																																								
D	2015	Spark EV	Body	HVAC Control Module																																																								
D	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																								
D	2015	Spark EV	Body	Coolant Heater Control Module																																																								
D	2015	Spark EV	Body	Keyless Entry Control Module																																																								
D	2015	Spark EV	Body	Battery Charger Control Module																																																								
D	2015	Spark EV	Body	DC Charging Control Module																																																								
D	2015	Spark EV	Body	Battery Energy Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
D	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																								
D	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																								
D	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																								
D	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																								
D	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																								
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																								
D	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																								
D	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
D	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																								
D	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
D	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																								
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
D	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																								
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																								
D	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																								
D	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																								
D	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																								
D	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
D	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																								
D	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																								
D	2016	Spark	Powertrain	Fuel Injector Control Module																																																								
D	2016	Spark	Chassis	Electronic Brake Control Module																																																								
D	2016	Spark	Chassis	Electronic Brake Control Module																																																								
D	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
D	2016	Spark	Chassis	Power Steering Control Module																																																								
D	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
D	2016	Spark	Body	Body Control Module																																																								
D	2016	Spark	Body	Body Control Module																																																								
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2016	Spark	Body	Instrument Cluster																																																								
D	2016	Spark	Body	Instrument Cluster																																																								
D	2016	Spark	Body	Radio																																																								
D	2016	Spark	Body	Telematics Communication Interface Control Module																																																								
D	2016	Spark	Body	Keyless Entry Control Module																																																								
D	2016	Spark EV	Powertrain	Engine Control Module																																																								
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																								
D	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																								
D	2016	Spark EV	Powertrain	Drive Motor Control Module																																																								
D	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								
D	2016	Spark EV	Chassis	Electronic Brake Control Module																																																								
D	2016	Spark EV	Chassis	Parking Brake Control Module																																																								
D	2016	Spark EV	Chassis	Power Steering Control Module																																																								
D	2016	Spark EV	Body	Body Control Module																																																								
D	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
D	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
D	2016	Spark EV	Body	Passenger Presence Module																																																								
D	2016	Spark EV	Body	Instrument Cluster																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
D	2016	Spark EV	Body	Radio																																																								
D	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																								
D	2016	Spark EV	Body	HVAC Control Module																																																								
D	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																								
D	2016	Spark EV	Body	Coolant Heater Control Module																																																								
D	2016	Spark EV	Body	Keyless Entry Control Module																																																								
D	2016	Spark EV	Body	Frontview Camera Module																																																								
D	2016	Spark EV	Body	Battery Charger Control Module																																																								
D	2016	Spark EV	Body	DC Charging Control Module																																																								
D	2016	Spark EV	Body	Battery Energy Control Module																																																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Automatic Transmission																																																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Engine Control Module Manual Transmission																																																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Fuel Pump Control Module																																																								
F	2010	Camaro	Powertrain	(V) 3.6L LLT Transmission Control Module																																																								
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																								
F	2010	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2010	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																								
F	2010	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																								
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																								
F	2010	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2010	Camaro	Chassis	Electronic Brake Control Module																																																								
F	2010	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																								
F	2010	Camaro	Chassis	Power Steering Control Module																																																								
F	2010	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2010	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
F	2010	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
F	2010	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2010	Camaro	Body	Passenger Presence Module																																																								
F	2010	Camaro	Body	Instrument Cluster																																																								
F	2010	Camaro	Body	Auxiliary Gage Module																																																								
F	2010	Camaro	Body	Radio																																																								
F	2010	Camaro	Body	Multimedia Player Interface Module																																																								
F	2010	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																								
F	2010	Camaro	Body	Mobile Telephone Control Module																																																								
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																								
F	2010	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2010	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																								
F	2010	Camaro	Body	Front Seat Heating Control Module																																																								
F	2010	Camaro	Body	Folding Top Control Module																																																								
F	2010	Camaro	Body	Parking Assist Control Module																																																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Automatic Transmission																																																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Engine Control Module Manual Transmission																																																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Fuel Pump Control Module																																																								
F	2011	Camaro	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																								
F	2011	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2011	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																								
F	2011	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																								
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																								
F	2011	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2011	Camaro	Chassis	Electronic Brake Control Module																																																								
F	2011	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																								
F	2011	Camaro	Chassis	Power Steering Control Module																																																								
F	2011	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2011	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
F	2011	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
F	2011	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2011	Camaro	Body	Passenger Presence Module																																																								
F	2011	Camaro	Body	Instrument Cluster																																																								
F	2011	Camaro	Body	Head-Up Display Module																																																								
F	2011	Camaro	Body	Auxiliary Gage Module																																																								
F	2011	Camaro	Body	Headlamp Control Module																																																								
F	2011	Camaro	Body	Radio																																																								
F	2011	Camaro	Body	Multimedia Player Interface Module																																																								
F	2011	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																								
F	2011	Camaro	Body	Mobile Telephone Control Module																																																								
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																								
F	2011	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2011	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																								
F	2011	Camaro	Body	Front Seat Heating Control Module																																																								
F	2011	Camaro	Body	Folding Top Control Module																																																								
F	2011	Camaro	Body	Parking Assist Control Module																																																								
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
F	2012	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
F	2012	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																								
F	2012	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																								
F	2012	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2012	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Control Module																																																								
F	2012	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																								
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Control Module																																																								
F	2012	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																								
F	2012	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																								
F	2012	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Control Module																																																								
F	2012	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																								
F	2012	Camaro	Chassis	Electronic Brake Control Module																																																								
F	2012	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																								
F	2012	Camaro	Chassis	Power Steering Control Module																																																								
F	2012	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2012	Camaro	Chassis	Suspension Control Module																																																								
F	2012	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
F	2012	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
F	2012	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2012	Camaro	Body	Passenger Presence Module																																																								
F	2012	Camaro	Body	Instrument Cluster																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
F	2012	Camaro	Body	Head-Up Display Module																																																								
F	2012	Camaro	Body	Auxiliary Gage Module																																																								
F	2012	Camaro	Body	Headlamp Control Module																																																								
F	2012	Camaro	Body	Radio																																																								
F	2012	Camaro	Body	Multimedia Player Interface Module																																																								
F	2012	Camaro	Body	Telematics Vehicle Localization and Immobilization Control Module																																																								
F	2012	Camaro	Body	Mobile Telephone Control Module																																																								
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																								
F	2012	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2012	Camaro	Body	Remote Heater and Air Conditioning Control Module																																																								
F	2012	Camaro	Body	Front Seat Heating Control Module																																																								
F	2012	Camaro	Body	Folding Top Control Module																																																								
F	2012	Camaro	Body	Parking Assist Control Module																																																								
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
F	2013	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump																																																								
F	2013	Camaro	Powertrain	(3) 3.6L LFX Fuel Pump Version Fuel Pump and Exhaust Flow																																																								
F	2013	Camaro	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																								
F	2013	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump																																																								
F	2013	Camaro	Powertrain	(J) 6.2L L99 Fuel Pump Version Fuel Pump and Exhaust Flow																																																								
F	2013	Camaro	Powertrain	(J) 6.2L L99 Transmission Control Module																																																								
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump																																																								
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Fuel Pump Version Fuel Pump and Exhaust Flow																																																								
F	2013	Camaro	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																								
F	2013	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																								
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump																																																								
F	2013	Camaro	Powertrain	(P) 6.2L LSA Fuel Pump Version Fuel Pump and Exhaust Flow																																																								
F	2013	Camaro	Powertrain	(P) 6.2L LSA Transmission Control Module																																																								
F	2013	Camaro	Chassis	Electronic Brake Control Module																																																								
F	2013	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																								
F	2013	Camaro	Chassis	Power Steering Control Module																																																								
F	2013	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2013	Camaro	Chassis	Suspension Control Module																																																								
F	2013	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
F	2013	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
F	2013	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2013	Camaro	Body	Passenger Presence Module																																																								
F	2013	Camaro	Body	Instrument Cluster																																																								
F	2013	Camaro	Body	Head-Up Display Module																																																								
F	2013	Camaro	Body	Auxiliary Gage Module																																																								
F	2013	Camaro	Body	Headlamp Control Module																																																								
F	2013	Camaro	Body	Radio																																																								
F	2013	Camaro	Body	Multimedia Player Interface Module																																																								
F	2013	Camaro	Body	Mobile Telephone Control Module																																																								
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																								
F	2013	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
F	2013	Camaro	Body	HVAC Control Module																																																								
F	2013	Camaro	Body	Front Seat Heating Control Module																																																									
F	2013	Camaro	Body	Folding Top Control Module																																																									
F	2013	Camaro	Body	Parking Assist Control Module																																																									
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
F	2014	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																									
F	2014	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																									
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																									
F	2014	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																									
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																									
F	2014	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																									
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																									
F	2014	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																									
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																									
F	2014	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																									
F	2014	Camaro	Powertrain	Transmission Control Module																																																									
F	2014	Camaro	Chassis	Electronic Brake Control Module																																																									
F	2014	Camaro	Chassis	Parking Brake Control Module																																																									
F	2014	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																									
F	2014	Camaro	Chassis	Power Steering Control Module																																																									
F	2014	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																									
F	2014	Camaro	Chassis	Suspension Control Module																																																									
F	2014	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
F	2014	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
F	2014	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
F	2014	Camaro	Body	Passenger Presence Module																																																									
F	2014	Camaro	Body	Instrument Cluster																																																									
F	2014	Camaro	Body	Head-Up Display Module																																																									
F	2014	Camaro	Body	Auxiliary Gage Module																																																									
F	2014	Camaro	Body	Headlamp Control Module																																																									
F	2014	Camaro	Body	Radio																																																									
F	2014	Camaro	Body	Mobile Telephone Control Module																																																									
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 9																																																									
F	2014	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																									
F	2014	Camaro	Body	HVAC Control Module																																																									
F	2014	Camaro	Body	Front Seat Heating Control Module																																																									
F	2014	Camaro	Body	Folding Top Control Module																																																									
F	2014	Camaro	Body	Parking Assist Control Module																																																									
F	2014	SS	Powertrain	(W) 6.2L LS3 Engine Control Module																																																									
F	2014	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																									
F	2014	SS	Powertrain	Chassis Control Module																																																									
F	2014	SS	Chassis	Electronic Brake Control Module																																																									
F	2014	SS	Chassis	Parking Brake Control Module																																																									
F	2014	SS	Chassis	Power Steering Control Module																																																									
F	2014	SS	Chassis	Steering Wheel Angle Sensor Module																																																									
F	2014	SS	Body	Body Control Module																																																									
F	2014	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
F	2014	SS	Body	Passenger Presence Module																																																									
F	2014	SS	Body	Instrument Cluster																																																									
F	2014	SS	Body	Head-Up Display Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
F	2014	SS	Body	Radio Control																																																								
F	2014	SS	Body	HVAC Control																																																								
F	2014	SS	Body	Headlamp Control Module																																																								
F	2014	SS	Body	Trailer Interface Control Module																																																								
F	2014	SS	Body	Radio																																																								
F	2014	SS	Body	Telematics Communication Interface Control Module Version 9																																																								
F	2014	SS	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2014	SS	Body	HVAC Control Module																																																								
F	2014	SS	Body	Seat Memory Control Module - Driver																																																								
F	2014	SS	Body	Keyless Entry Control Module																																																								
F	2014	SS	Body	Right Side Object Detection Control Module																																																								
F	2014	SS	Body	Left Side Object Detection Control Module																																																								
F	2014	SS	Body	Parking Assist Control Module																																																								
F	2014	SS	Body	Frontview Camera Module																																																								
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
F	2015	Camaro	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Automatic Transmission																																																								
F	2015	Camaro	Powertrain	(J) 6.2L L99 Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2015	Camaro	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Automatic Transmission																																																								
F	2015	Camaro	Powertrain	(P) 6.2L LSA Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Automatic Transmission																																																								
F	2015	Camaro	Powertrain	(E) 7.0L LS7 Engine Control Module Manual Transmission																																																								
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump																																																								
F	2015	Camaro	Powertrain	Chassis Control Version Fuel Pump and Exhaust Flow																																																								
F	2015	Camaro	Powertrain	Transmission Control Module																																																								
F	2015	Camaro	Chassis	Electronic Brake Control Module																																																								
F	2015	Camaro	Chassis	Multi-Axis Acceleration Sensor Module																																																								
F	2015	Camaro	Chassis	Power Steering Control Module																																																								
F	2015	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2015	Camaro	Chassis	Suspension Control Module																																																								
F	2015	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
F	2015	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
F	2015	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2015	Camaro	Body	Passenger Presence Module																																																								
F	2015	Camaro	Body	Instrument Cluster																																																								
F	2015	Camaro	Body	Head-Up Display Module																																																								
F	2015	Camaro	Body	Auxiliary Gage Module																																																								
F	2015	Camaro	Body	Headlamp Control Module																																																								
F	2015	Camaro	Body	Radio																																																								
F	2015	Camaro	Body	Mobile Telephone Control Module																																																								
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.6																																																								
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																								
F	2015	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2015	Camaro	Body	HVAC Control Module																																																								
F	2015	Camaro	Body	Front Seat Heating Control Module																																																								
F	2015	Camaro	Body	Folding Top Control Module																																																								
F	2015	Camaro	Body	Parking Assist Control Module																																																								
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2015	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
F	2015	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2015	SS	Powertrain	Fuel Injector Control Module																																																								
F	2015	SS	Powertrain	Chassis Control Module																																																								
F	2015	SS	Chassis	Electronic Brake Control Module																																																								
F	2015	SS	Chassis	Parking Brake Control Module																																																								
F	2015	SS	Chassis	Power Steering Control Module																																																								
F	2015	SS	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2015	SS	Chassis	Suspension Control Module																																																								
F	2015	SS	Body	Body Control Module																																																								
F	2015	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2015	SS	Body	Passenger Presence Module																																																								
F	2015	SS	Body	Instrument Cluster																																																								
F	2015	SS	Body	Head-Up Display Module																																																								
F	2015	SS	Body	Radio Control																																																								
F	2015	SS	Body	HVAC Control																																																								
F	2015	SS	Body	Headlamp Control Module																																																								
F	2015	SS	Body	Trailer Interface Control Module																																																								
F	2015	SS	Body	Radio																																																								
F	2015	SS	Body	Telematics Communication Interface Control Module																																																								
F	2015	SS	Body	HVAC Control Module																																																								
F	2015	SS	Body	Seat Memory Control Module - Driver																																																								
F	2015	SS	Body	Keyless Entry Control Module																																																								
F	2015	SS	Body	Right Side Object Detection Control Module																																																								
F	2015	SS	Body	Left Side Object Detection Control Module																																																								
F	2015	SS	Body	Parking Assist Control Module																																																								
F	2015	SS	Body	Frontview Camera Module																																																								
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																								
F	2016	Camaro	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																								
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Automatic Transmission																																																								
F	2016	Camaro	Powertrain	(S) 3.6L LGX Engine Control Module Manual Transmission																																																								
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																								
F	2016	Camaro	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																								
F	2016	Camaro	Powertrain	Transmission Control Module																																																								
F	2016	Camaro	Chassis	Electronic Brake Control Module																																																								
F	2016	Camaro	Chassis	Parking Brake Control Module																																																								
F	2016	Camaro	Chassis	Power Steering Control Module																																																								
F	2016	Camaro	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2016	Camaro	Chassis	Suspension Control Module																																																								
F	2016	Camaro	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
F	2016	Camaro	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
F	2016	Camaro	Body	Serial Data Gateway Module																																																								
F	2016	Camaro	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2016	Camaro	Body	Passenger Presence Module																																																								
F	2016	Camaro	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																								
F	2016	Camaro	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																								
F	2016	Camaro	Body	Head-Up Display Module																																																								
F	2016	Camaro	Body	Auxiliary Gage Module																																																								
F	2016	Camaro	Body	Radio Controls																																																								
F	2016	Camaro	Body	HVAC Controls																																																								
F	2016	Camaro	Body	Vehicle Performance Data Recorder																																																								
F	2016	Camaro	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
F	2016	Camaro	Body	Amplifier																																																								
F	2016	Camaro	Body	Media Disc Player																																																								
F	2016	Camaro	Body	Human Machine Interface Control Module																																																								
F	2016	Camaro	Body	Navigation Control Module																																																								
F	2016	Camaro	Body	Mobile Telephone Control Module																																																								
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 9.7																																																								
F	2016	Camaro	Body	Telematics Communication Interface Control Module Version 10																																																								
F	2016	Camaro	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
F	2016	Camaro	Body	HVAC Auto Control Single Zone (C68)																																																								
F	2016	Camaro	Body	Seat Memory Control Module - Driver																																																								
F	2016	Camaro	Body	Folding Top Control Module																																																								
F	2016	Camaro	Body	Keyless Entry Control Module																																																								
F	2016	Camaro	Body	Right Side Object Detection Control Module																																																								
F	2016	Camaro	Body	Left Side Object Detection Control Module																																																								
F	2016	Camaro	Body	Parking Assist Control Module																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Automatic Transmission																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Engine Control Module Manual Transmission																																																								
F	2016	SS	Powertrain	(W) 6.2L LS3 Transmission Control Module																																																								
F	2016	SS	Powertrain	Fuel Injector Control Module																																																								
F	2016	SS	Chassis	Electronic Brake Control Module																																																								
F	2016	SS	Chassis	Parking Brake Control Module																																																								
F	2016	SS	Chassis	Power Steering Control Module																																																								
F	2016	SS	Chassis	Steering Wheel Angle Sensor Module																																																								
F	2016	SS	Chassis	Suspension Control Module																																																								
F	2016	SS	Body	Body Control Module																																																								
F	2016	SS	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
F	2016	SS	Body	Passenger Presence Module																																																								
F	2016	SS	Body	Instrument Cluster																																																								
F	2016	SS	Body	Head-Up Display Module																																																								
F	2016	SS	Body	Radio Control																																																								
F	2016	SS	Body	HVAC Control																																																								
F	2016	SS	Body	Trailer Interface Control Module																																																								
F	2016	SS	Body	Radio																																																								
F	2016	SS	Body	Telematics Communication Interface Control Module																																																								
F	2016	SS	Body	HVAC Control Module																																																								
F	2016	SS	Body	Seat Memory Control Module - Driver																																																								
F	2016	SS	Body	Keyless Entry Control Module																																																								
F	2016	SS	Body	Right Side Object Detection Control Module																																																								
F	2016	SS	Body	Left Side Object Detection Control Module																																																								
F	2016	SS	Body	Parking Assist Control Module																																																								
F	2016	SS	Body	Frontview Camera Module																																																								
G	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
G	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
G	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
G	2016	Malibu	Powertrain	Fuel Injector Control Module																																																								
G	2016	Malibu	Powertrain	Chassis Control Module																																																								
G	2016	Malibu	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2016	Malibu	Chassis	Parking Brake Control Module																																																									
G	2016	Malibu	Chassis	Power Steering Control Module																																																										
G	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
G	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
G	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
G	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2016	Malibu	Body	Passenger Presence Module																																																										
G	2016	Malibu	Body	Instrument Cluster																																																										
G	2016	Malibu	Body	Headlamp Control Module																																																										
G	2016	Malibu	Body	Radio																																																										
G	2016	Malibu	Body	Digital Radio Receiver Control Module																																																										
G	2016	Malibu	Body	Multimedia Player Interface Module																																																										
G	2016	Malibu	Body	Mobile Telephone Control Module																																																										
G	2016	Malibu	Body	Telematics Communication Interface Control Module																																																										
G	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																										
G	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																										
G	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																										
G	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																										
G	2016	Malibu	Body	Seat Memory Control Module																																																										
G	2016	Malibu	Body	Front Seat Heating Control Module																																																										
G	2016	Malibu	Body	Rear Seat Heating Control Module																																																										
G	2016	Malibu	Body	Keyless Entry Control Module																																																										
G	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
G	2016	Malibu	Body	Parking Assist Control Module																																																										
G	2016	Malibu	Body	Frontview Camera Module																																																										
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
H	2010	Sail	Powertrain	Transmission Control Module																																																										
H	2010	Sail	Chassis	Electronic Brake Control Module																																																										
H	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
H	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																										
H	2011	Sail	Powertrain	Transmission Control Module																																																										
H	2011	Sail	Chassis	Electronic Brake Control Module																																																										
H	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																										
H	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																										
H	2012	Sail	Powertrain	Transmission Control Module																																																										
H	2012	Sail	Chassis	Electronic Brake Control Module																																																										
H	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																										
H	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																										
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
H	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
H	2013	Sail	Powertrain	Transmission Control Module																																																								
H	2013	Sail	Chassis	Electronic Brake Control Module																																																								
H	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
H	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								
H	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
H	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
H	2014	Sail	Powertrain	Transmission Control Module																																																								
H	2014	Sail	Chassis	Electronic Brake Control Module																																																								
H	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																								
H	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																								
H	2015	Sail	Chassis	Electronic Brake Control Module																																																								
H	2015	Sail	Chassis	Power Steering Control Module																																																								
H	2015	Sail	Body	Body Control Module																																																								
H	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2015	Sail	Body	Radio/HVAC Control																																																								
H	2015	Sail	Body	HVAC Control Module																																																								
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																								
H	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																								
H	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																								
H	2016	Sail	Chassis	Electronic Brake Control Module																																																								
H	2016	Sail	Chassis	Power Steering Control Module																																																								
H	2016	Sail	Body	Body Control Module																																																								
H	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2016	Sail	Body	Radio/HVAC Control																																																								
H	2016	Sail	Body	Radio																																																								
H	2016	Sail	Body	HVAC Control Module																																																								
J	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
J	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
J	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
J	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																								
J	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
J	2004	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																								
J	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																								
J	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																								
J	2004	Optra	Body	Remote Function Actuation																																																								
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
J	2004	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel																																																								
J	2004	Cavalier	Powertrain	(6)2.2L L4 L42 Alternative Fuel Transmission Control Module																																																								
J	2004	Cavalier	Chassis	Anti-lock Brake System																																																								
J	2004	Cavalier	Body	Body Control Module																																																								
J	2004	Cavalier	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2004	Cavalier	Body	Instrument Panel Cluster																																																								
J	2004	Cavalier	Body	Radio																																																								
J	2004	Cavalier	Body	Supplemental Inflatable Restraint																																																								
J	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
J	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
J	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
J	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																								
J	2005	Optra	Powertrain	ML4/MLQ 4 Speed Automatic																																																								
J	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																								
J	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																								
J	2005	Optra	Body	Remote Function Actuation																																																								
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
J	2005	Cavalier	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
J	2005	Cavalier	Chassis	Anti-lock Brake System																																																								
J	2005	Cavalier	Body	Body Control Module																																																								
J	2005	Cavalier	Body	Digital Radio Receiver																																																								
J	2005	Cavalier	Body	Instrument Panel Cluster																																																								
J	2005	Cavalier	Body	Radio																																																								
J	2005	Cavalier	Body	Supplemental Inflatable Restraint																																																								
J	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
J	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
J	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
J	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																								
J	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
J	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
J	2006	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																								
J	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
J	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																								
J	2006	ALL	Body	Remote Function Actuation																																																								
J	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
J	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
J	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
J	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
J	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
J	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
J	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																								
J	2007	ALL	Powertrain	4 Speed Automatic																																																								
J	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																								
J	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																								
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																								
J	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																								
J	2007	ALL	Chassis	Tire Pressure Monitor																																																								
J	2007	ALL	Body	Remote Function Actuation																																																								
J	2007	ALL	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
J	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																								
J	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
J	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
J	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
J	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																								
J	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
J	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																																																								
J	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																								
J	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
J	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																								
J	2008	ALL	Chassis	Tire Pressure Monitor																																																								
J	2008	ALL	Body	Remote Function Actuation																																																								
J	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
J	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
J	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																								
J	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
J	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
J	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
J	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																								
J	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
J	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																								
J	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
J	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																								
J	2009	ALL	Chassis	Tire Pressure Monitor																																																								
J	2009	ALL	Body	Remote Function Actuation																																																								
J	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																								
J	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																								
J	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																								
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																								
J	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																								
J	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																								
J	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																								
J	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																								
J	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																								
J	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																								
J	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																								
J	2010	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2010	Cruze	Body	Body Control Module																																																								
J	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2010	Cruze	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2010	Cruze	Body	Instrument Cluster																																																								
J	2010	Cruze	Body	Trailer Interface Control Module																																																								
J	2010	Cruze	Body	Radio																																																								
J	2010	Cruze	Body	Multimedia Player Interface Module																																																								
J	2010	Cruze	Body	Mobile Telephone Control Module																																																								
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																								
J	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																								
J	2010	Cruze	Body	Keyless Entry Control Module																																																								
J	2010	Cruze	Body	Parking Assist Control Module																																																								
J	2010	Cruze	Body	Steering Column Lock Control Module																																																								
J	2010	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
J	2010	Other	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																								
J	2010	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
J	2010	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																								
J	2010	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
J	2010	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2010	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2010	Other	Powertrain	Transmission Control Module 5 Speed																																																								
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
J	2010	Other	Chassis	Electronic Brake Control Module Traction Control No																																																								
J	2010	Other	Chassis	Tire Pressure Monitor																																																								
J	2010	Other	Body	Remote Function Actuation																																																								
J	2010	Other	Body	Supplemental Inflatable Restraint																																																								
J	2010	Other	Body	Supplemental Inflatable Restraint																																																								
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																								
J	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																								
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
J	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
J	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																								
J	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																								
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																								
J	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																								
J	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																								
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
J	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
J	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																								
J	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																								
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																								
J	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																								
J	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																								
J	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																								
J	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																									
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
J	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
J	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
J	2011	Cruze	Chassis	Electronic Brake Control Module																																																									
J	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2011	Cruze	Body	Body Control Module																																																									
J	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2011	Cruze	Body	Passenger Presence Module																																																									
J	2011	Cruze	Body	Instrument Cluster																																																									
J	2011	Cruze	Body	Trailer Interface Control Module																																																									
J	2011	Cruze	Body	Radio																																																									
J	2011	Cruze	Body	Multimedia Player Interface Module																																																									
J	2011	Cruze	Body	Mobile Telephone Control Module																																																									
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
J	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
J	2011	Cruze	Body	Keyless Entry Control Module																																																									
J	2011	Cruze	Body	Parking Assist Control Module																																																									
J	2011	Cruze	Body	Steering Column Lock Control Module																																																									
J	2011	Other	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
J	2011	Other	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
J	2011	Other	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																									
J	2011	Other	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																									
J	2011	Other	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
J	2011	Other	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
J	2011	Other	Powertrain	MFA Transmission Control Module 4 Speed																																																									
J	2011	Other	Powertrain	Transmission Control Module 5 Speed																																																									
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
J	2011	Other	Chassis	Electronic Brake Control Module Traction Control No																																																									
J	2011	Other	Chassis	Tire Pressure Monitor																																																									
J	2011	Other	Body	Remote Function Actuation																																																									
J	2011	Other	Body	Supplemental Inflatable Restraint																																																									
J	2011	Other	Body	Supplemental Inflatable Restraint																																																									
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																									
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																								
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																								
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2012	Aveo	Powertrain	Fuel Pump Control Module																																																								
J	2012	Aveo	Powertrain	Fuel Injector Control Module																																																								
J	2012	Aveo	Chassis	Electronic Brake Control Module																																																								
J	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2012	Aveo	Chassis	Electric Power Steering Control Module																																																								
J	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2012	Aveo	Body	Body Control Module Hatchback																																																								
J	2012	Aveo	Body	Body Control Module Sedan																																																								
J	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2012	Aveo	Body	Passenger Presence Module																																																								
J	2012	Aveo	Body	Instrument Cluster																																																								
J	2012	Aveo	Body	Radio																																																								
J	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																								
J	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
J	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								
J	2012	Aveo	Body	Front Seat Heating Control Module																																																								
J	2012	Aveo	Body	Parking Assist Control Module																																																								
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2012	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2012	Cobalt	Powertrain	1.3L LDV Transmission Control Module																																																								
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2012	Cobalt	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2012	Cobalt	Powertrain	1.3L LSF Transmission Control Module																																																								
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																								
J	2012	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																								
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																								
J	2012	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
J	2012	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																								
J	2012	Cobalt	Chassis	Electronic Brake Control Module																																																								
J	2012	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2012	Cobalt	Chassis	Electric Power Steering Control Module																																																								
J	2012	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2012	Cobalt	Body	Body Control Module																																																								
J	2012	Cobalt	Body	Passenger Presence Module																																																								
J	2012	Cobalt	Body	Instrument Cluster																																																								
J	2012	Cobalt	Body	Radio																																																								
J	2012	Cobalt	Body	Telematic Vehicle Localization and Immobilization Control Module																																																								
J	2012	Cobalt	Body	Telematics Communication Interface Control Module																																																								
J	2012	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2012	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2012	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																								
J	2012	Cobalt	Body	Front Seat Heating Control Module																																																								
J	2012	Cobalt	Body	Parking Assist Control Module																																																								
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																								
J	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																								
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
J	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
J	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																								
J	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																								
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																								
J	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																								
J	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																								
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
J	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
J	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																								
J	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																								
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																								
J	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																								
J	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
J	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																								
J	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																								
J	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																								
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																								
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																								
J	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																								
J	2012	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2012	Cruze	Body	Body Control Module Hatchback																																																								
J	2012	Cruze	Body	Body Control Module Sedan																																																								
J	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2012	Cruze	Body	Passenger Presence Module																																																								
J	2012	Cruze	Body	Instrument Cluster																																																								
J	2012	Cruze	Body	Trailer Interface Control Module																																																								
J	2012	Cruze	Body	Radio																																																								
J	2012	Cruze	Body	Multimedia Player Interface Module																																																								
J	2012	Cruze	Body	Mobile Telephone Control Module																																																								
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																								
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																								
J	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																								
J	2012	Cruze	Body	Keyless Entry Control Module																																																								
J	2012	Cruze	Body	Parking Assist Control Module																																																								
J	2012	Cruze	Body	Steering Column Lock Control Module																																																								
J	2012	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
J	2012	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								
J	2012	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
J	2012	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																								
J	2012	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2012	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2012	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																								
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
J	2012	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																								
J	2012	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																								
J	2012	Sonic (First Gen)	Body	Remote Function Actuation																																																								
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																								
J	2012	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LDV Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.3L LSF Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LDE Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	1.6L LFJ Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2012	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																								
J	2012	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																								
J	2012	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2012	Sonic (Second Gen)	Chassis	Electric Power Steering Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module Chassis Expansion CAN BUS																																																								
J	2012	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module High Speed CAN Bus																																																								
J	2012	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																								
J	2012	Sonic (Second Gen)	Body	Body Control Module Sedan																																																								
J	2012	Sonic (Second Gen)	Body	Passenger Presence Module																																																								
J	2012	Sonic (Second Gen)	Body	Instrument Cluster																																																								
J	2012	Sonic (Second Gen)	Body	Radio																																																								
J	2012	Sonic (Second Gen)	Body	Telematic Vehicle Localization and Immobilization Control Module																																																								
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2012	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																								
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2012	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																								
J	2012	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																								
J	2012	Sonic (Second Gen)	Body	Parking Assist Control Module																																																								
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
J	2013	Aveo	Powertrain	Fuel Pump Control Module																																																								
J	2013	Aveo	Powertrain	Fuel Injector Control Module																																																								
J	2013	Aveo	Chassis	Electronic Brake Control Module																																																								
J	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Aveo	Chassis	Electric Power Steering Control Module																																																								
J	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2013	Aveo	Body	Body Control Module Hatchback																																																								
J	2013	Aveo	Body	Body Control Module Sedan																																																								
J	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2013	Aveo	Body	Passenger Presence Module																																																								
J	2013	Aveo	Body	Instrument Cluster																																																								
J	2013	Aveo	Body	Radio																																																								
J	2013	Aveo	Body	Telematics Communication Interface Control Module																																																								
J	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
J	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								
J	2013	Aveo	Body	Front Seat Heating Control Module																																																								
J	2013	Aveo	Body	Parking Assist Control Module																																																								
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2013	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																									
J	2013	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																									
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																									
J	2013	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																									
J	2013	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																									
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
J	2013	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
J	2013	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																									
J	2013	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																									
J	2013	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																									
J	2013	Cobalt	Chassis	Electronic Brake Control Module																																																									
J	2013	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2013	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2013	Cobalt	Body	Body Control Module																																																									
J	2013	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2013	Cobalt	Body	Instrument Cluster																																																									
J	2013	Cobalt	Body	Radio																																																									
J	2013	Cobalt	Body	Telematics Communication Interface Control Module																																																									
J	2013	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									
J	2013	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2013	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
J	2013	Cobalt	Body	Front Seat Heating Control Module																																																									
J	2013	Cobalt	Body	Parking Assist Control Module																																																									
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
J	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																									
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																									
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																									
J	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																									
J	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
J	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																									
J	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																									
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																									
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																									
J	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																									
J	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																									
J	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																									
J	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
J	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																									
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
J	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																								
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																								
J	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
J	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																								
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
J	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
J	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
J	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
J	2013	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2013	Cruze	Body	Body Control Module Hatchback																																																								
J	2013	Cruze	Body	Body Control Module Sedan																																																								
J	2013	Cruze	Body	Body Control Module Station Wagon																																																								
J	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2013	Cruze	Body	Passenger Presence Module																																																								
J	2013	Cruze	Body	Instrument Cluster																																																								
J	2013	Cruze	Body	Trailer Interface Control Module																																																								
J	2013	Cruze	Body	Radio																																																								
J	2013	Cruze	Body	Digital Radio Receiver Control Module																																																								
J	2013	Cruze	Body	Multimedia Player Interface Module																																																								
J	2013	Cruze	Body	Mobile Telephone Control Module																																																								
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																								
J	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																								
J	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																								
J	2013	Cruze	Body	Front Seat Heating Control Module																																																								
J	2013	Cruze	Body	Keyless Entry Control Module																																																								
J	2013	Cruze	Body	Right Side Object Detection Control Module																																																								
J	2013	Cruze	Body	Left Side Object Detection Control Module																																																								
J	2013	Cruze	Body	Parking Assist Control Module																																																								
J	2013	Cruze	Body	Steering Column Lock Control Module																																																								
J	2013	Sonic (First Gen)	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
J	2013	Sonic (First Gen)	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								
J	2013	Sonic (First Gen)	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
J	2013	Sonic (First Gen)	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																								
J	2013	Sonic (First Gen)	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
J	2013	Sonic (First Gen)	Powertrain	MFA Transmission Control Module 4 Speed																																																								
J	2013	Sonic (First Gen)	Powertrain	Transmission Control Module 5 Speed																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
J	2013	Sonic (First Gen)	Chassis	Electronic Brake Control Module Traction Control No																																																								
J	2013	Sonic (First Gen)	Chassis	Tire Pressure Monitor																																																								
J	2013	Sonic (First Gen)	Body	Remote Function Actuation																																																								
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																								
J	2013	Sonic (First Gen)	Body	Supplemental Inflatable Restraint																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.2L LDC Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L L2N Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	1.4L LDD Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(C) 1.6L LDE Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2013	Sonic (Second Gen)	Powertrain	(G) 1.8L LWE Fuel Pump Control Module																																																								
J	2013	Sonic (Second Gen)	Chassis	Electronic Brake Control Module																																																								
J	2013	Sonic (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Sonic (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2013	Sonic (Second Gen)	Body	Body Control Module Hatchback																																																								
J	2013	Sonic (Second Gen)	Body	Body Control Module Sedan																																																								
J	2013	Sonic (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2013	Sonic (Second Gen)	Body	Passenger Presence Module																																																								
J	2013	Sonic (Second Gen)	Body	Instrument Cluster																																																								
J	2013	Sonic (Second Gen)	Body	Radio																																																								
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2013	Sonic (Second Gen)	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Heater Only (C41)																																																								
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2013	Sonic (Second Gen)	Body	HVAC Control Module Single Zone (C60)																																																									
J	2013	Sonic (Second Gen)	Body	Front Seat Heating Control Module																																																									
J	2013	Sonic (Second Gen)	Body	Parking Assist Control Module																																																									
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2013	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2013	Spin	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
J	2013	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
J	2013	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																									
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																									
J	2013	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																									
J	2013	Spin	Powertrain	1.8L LMD Transmission Control Module																																																									
J	2013	Spin	Chassis	Electronic Brake Control Module																																																									
J	2013	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2013	Spin	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2013	Spin	Body	Body Control Module																																																									
J	2013	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2013	Spin	Body	Instrument Cluster																																																								
J	2013	Spin	Body	Radio																																																								
J	2013	Spin	Body	HVAC Control Module Heater Only (C41)																																																								
J	2013	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2013	Spin	Body	HVAC Control Module Single Zone (C60)																																																								
J	2013	Spin	Body	Parking Assist Control Module																																																								
J	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																								
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
J	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																								
J	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																								
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																								
J	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																								
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																								
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
J	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																										
J	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																										
J	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																										
J	2014	Aveo	Powertrain	Chassis Control Module																																																										
J	2014	Aveo	Powertrain	Fuel Injector Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Electronic Brake Control Module																																																										
J	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Aveo	Chassis	Power Steering Control Module																																																										
J	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Aveo	Body	Body Control Module Hatchback																																																										
J	2014	Aveo	Body	Body Control Module Sedan																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Aveo	Body	Instrument Cluster																																																										
J	2014	Aveo	Body	Radio																																																										
J	2014	Aveo	Body	Telematics Communication Interface Control Module																																																										
J	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Aveo	Body	Front Seat Heating Control Module																																																										
J	2014	Aveo	Body	Keyless Entry Control Module																																																										
J	2014	Aveo	Body	Parking Assist Control Module																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																										
J	2014	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																										
J	2014	Cobalt	Chassis	Electronic Brake Control Module																																																										
J	2014	Cobalt	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2014	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Cobalt	Body	Body Control Module																																																										
J	2014	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Cobalt	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2014	Cobalt	Body	Radio																																																								
J	2014	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																								
J	2014	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2014	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																								
J	2014	Cobalt	Body	Front Seat Heating Control Module																																																								
J	2014	Cobalt	Body	Parking Assist Control Module																																																								
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																								
J	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																								
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																								
J	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																								
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																								
J	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																								
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																								
J	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
J	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
J	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
J	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																								
J	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																								
J	2014	Cruze	Powertrain	Fuel Injector Control Module																																																								
J	2014	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2014	Cruze	Chassis	Power Steering Control Module																																																								
J	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2014	Cruze	Body	Body Control Module Hatchback																																																								
J	2014	Cruze	Body	Body Control Module Sedan																																																								
J	2014	Cruze	Body	Body Control Module Station Wagon																																																								
J	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2014	Cruze	Body	Passenger Presence Module																																																								
J	2014	Cruze	Body	Instrument Cluster																																																								
J	2014	Cruze	Body	Trailer Interface Control Module																																																								
J	2014	Cruze	Body	Radio																																																								
J	2014	Cruze	Body	Digital Radio Receiver Control Module																																																								
J	2014	Cruze	Body	Multimedia Player Interface Module																																																								
J	2014	Cruze	Body	Mobile Telephone Control Module																																																								
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																								
J	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																								
J	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																								
J	2014	Cruze	Body	Front Seat Heating Control Module																																																								
J	2014	Cruze	Body	Keyless Entry Control Module																																																								
J	2014	Cruze	Body	Right Side Object Detection Control Module																																																								
J	2014	Cruze	Body	Left Side Object Detection Control Module																																																								
J	2014	Cruze	Body	Parking Assist Control Module																																																								
J	2014	Cruze	Body	Steering Column Lock Control Module																																																								
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.2L LDC Chassis Control Module																																																								
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2014	Sonic	Powertrain	1.4L LDD Chassis Control Module																																																								
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.4L LUJ Chassis Control Module																																																								
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2014	Sonic	Powertrain	(B) 1.4L LUV Chassis Control Module																																																								
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2014	Sonic	Powertrain	(C) 1.6L LDE Chassis Control Module																																																								
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	1.6L LED Transmission Control Module																																																								
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2014	Sonic	Powertrain	(H) 1.8L LUW Chassis Control Module																																																								
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
J	2014	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
J	2014	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2014	Sonic	Powertrain	(G) 1.8L LWE Chassis Control Module																																																								
J	2014	Sonic	Powertrain	Fuel Injector Control Module																																																								
J	2014	Sonic	Chassis	Electronic Brake Control Module																																																								
J	2014	Sonic	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2014	Sonic	Chassis	Power Steering Control Module																																																								
J	2014	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2014	Sonic	Body	Body Control Module Hatchback																																																								
J	2014	Sonic	Body	Body Control Module Sedan																																																								
J	2014	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2014	Sonic	Body	Passenger Presence Module																																																								
J	2014	Sonic	Body	Instrument Cluster																																																								
J	2014	Sonic	Body	Radio																																																								
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2014	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2014	Sonic	Body	HVAC Control Module Heater Only (C41)																																																								
J	2014	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2014	Sonic	Body	HVAC Control Module Single Zone (C60)																																																								
J	2014	Sonic	Body	Front Seat Heating Control Module																																																								
J	2014	Sonic	Body	Parking Assist Control Module																																																								
J	2014	Sonic	Body	Frontview Camera Module																																																								
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2014	Spin	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.5L L2B Transmission Control Module																																																								
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.8L LFQ Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																								
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																								
J	2014	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																								
J	2014	Spin	Powertrain	1.8L LMD Transmission Control Module																																																								
J	2014	Spin	Chassis	Electronic Brake Control Module																																																								
J	2014	Spin	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2014	Spin	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2014	Spin	Body	Body Control Module																																																								
J	2014	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2014	Spin	Body	Instrument Cluster																																																								
J	2014	Spin	Body	Radio																																																								
J	2014	Spin	Body	HVAC Control Module Heater Only (C41)																																																								
J	2014	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2014	Spin	Body	HVAC Control Module Single Zone (C60)																																																								
J	2014	Spin	Body	Parking Assist Control Module																																																								
J	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																								
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																								
J	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																								
J	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																								
J	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																								
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
J	2015	Aveo	Powertrain	Chassis Control Module																																																								
J	2015	Aveo	Powertrain	Fuel Injector Control Module																																																								
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																								
J	2015	Aveo	Chassis	Electronic Brake Control Module																																																								
J	2015	Aveo	Chassis	Power Steering Control Module																																																								
J	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2015	Aveo	Body	Body Control Module Hatchback																																																								
J	2015	Aveo	Body	Body Control Module Sedan																																																								
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Aveo	Body	Instrument Cluster																																																								
J	2015	Aveo	Body	Radio																																																								
J	2015	Aveo	Body	Telematics Communication Interface Control Module																																																								
J	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
J	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								
J	2015	Aveo	Body	Front Seat Heating Control Module																																																								
J	2015	Aveo	Body	Keyless Entry Control Module																																																								
J	2015	Aveo	Body	Parking Assist Control Module																																																								
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2015	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																								
J	2015	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																								
J	2015	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																								
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																								
J	2015	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																								
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																								
J	2015	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																								
J	2015	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																								
J	2015	Cobalt	Chassis	Electronic Brake Control Module																																																								
J	2015	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2015	Cobalt	Body	Body Control Module																																																								
J	2015	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Cobalt	Body	Instrument Cluster																																																								
J	2015	Cobalt	Body	Radio																																																								
J	2015	Cobalt	Body	Telematics Communication Interface Control Module																																																								
J	2015	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2015	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2015	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																								
J	2015	Cobalt	Body	Front Seat Heating Control Module																																																								
J	2015	Cobalt	Body	Parking Assist Control Module																																																								
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																								
J	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																								
J	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																								
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																								
J	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																								
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																								
J	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																								
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
J	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
J	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
J	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																								
J	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																								
J	2015	Cruze	Powertrain	Fuel Injector Control Module																																																								
J	2015	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2015	Cruze	Chassis	Power Steering Control Module																																																								
J	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2015	Cruze	Body	Body Control Module Hatchback																																																								
J	2015	Cruze	Body	Body Control Module Sedan																																																								
J	2015	Cruze	Body	Body Control Module Station Wagon																																																								
J	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Cruze	Body	Passenger Presence Module																																																								
J	2015	Cruze	Body	Instrument Cluster																																																								
J	2015	Cruze	Body	Trailer Interface Control Module																																																								
J	2015	Cruze	Body	Radio																																																								
J	2015	Cruze	Body	Digital Radio Receiver Control Module																																																								
J	2015	Cruze	Body	Multimedia Player Interface Module																																																								
J	2015	Cruze	Body	Mobile Telephone Control Module																																																								
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																								
J	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																								
J	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																								
J	2015	Cruze	Body	Front Seat Heating Control Module																																																								
J	2015	Cruze	Body	Keyless Entry Control Module																																																								
J	2015	Cruze	Body	Right Side Object Detection Control Module																																																								
J	2015	Cruze	Body	Left Side Object Detection Control Module																																																								
J	2015	Cruze	Body	Parking Assist Control Module																																																								
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2015	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																								
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	1.6L LED Transmission Control Module																																																								
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
J	2015	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
J	2015	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2015	Sonic	Powertrain	Chassis Control Module																																																								
J	2015	Sonic	Powertrain	Fuel Injector Control Module																																																								
J	2015	Sonic	Chassis	Electronic Brake Control Module																																																								
J	2015	Sonic	Chassis	Power Steering Control Module																																																								
J	2015	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2015	Sonic	Body	Body Control Module Hatchback																																																								
J	2015	Sonic	Body	Body Control Module Sedan																																																								
J	2015	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Sonic	Body	Passenger Presence Module																																																								
J	2015	Sonic	Body	Instrument Cluster																																																								
J	2015	Sonic	Body	Radio																																																								
J	2015	Sonic	Body	Telematics Communication Interface Control Module																																																								
J	2015	Sonic	Body	HVAC Control Module Heater Only (C41)																																																								
J	2015	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2015	Sonic	Body	HVAC Control Module Single Zone (C60)																																																								
J	2015	Sonic	Body	Front Seat Heating Control Module																																																								
J	2015	Sonic	Body	Parking Assist Control Module																																																								
J	2015	Sonic	Body	Frontview Camera Module																																																								
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2015	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2015	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																								
J	2015	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																								
J	2015	Spin	Powertrain	1.5L L2B Transmission Control Module																																																								
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2015	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																								
J	2015	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																									
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																									
J	2015	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																									
J	2015	Spin	Powertrain	1.8L LMD Transmission Control Module																																																									
J	2015	Spin	Chassis	Electronic Brake Control Module																																																									
J	2015	Spin	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2015	Spin	Body	Body Control Module																																																									
J	2015	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2015	Spin	Body	Instrument Cluster																																																									
J	2015	Spin	Body	Radio																																																									
J	2015	Spin	Body	Telematics Communication Interface Control Module																																																									
J	2015	Spin	Body	HVAC Control Module Heater Only (C41)																																																									
J	2015	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2015	Spin	Body	HVAC Control Module Single Zone (C60)																																																									
J	2015	Spin	Body	Front Seat Heating Control Module																																																									
J	2015	Spin	Body	Parking Assist Control Module																																																									
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
J	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
J	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
J	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																									
J	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																									
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
J	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
J	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																									
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																									
J	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
J	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																									
J	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																									
J	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																									
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																									
J	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																									
J	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																									
J	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																									
J	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
J	2016	Aveo	Powertrain	Chassis Control Module																																																									
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																								
J	2016	Aveo	Chassis	Electronic Brake Control Module																																																									
J	2016	Aveo	Chassis	Power Steering Control Module																																																									
J	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2016	Aveo	Body	Body Control Module Hatchback																																																									
J	2016	Aveo	Body	Body Control Module Sedan																																																									
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2016	Aveo	Body	Instrument Cluster																																																									
J	2016	Aveo	Body	Radio																																																									
J	2016	Aveo	Body	Telematics Communication Interface Control Module																																																									
J	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
J	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
J	2016	Aveo	Body	Front Seat Heating Control Module																																																									
J	2016	Aveo	Body	Parking Assist Control Module																																																									
J	2016	Aveo	Body	Keyless Entry Control Module																																																									
J	2016	Aveo	Body	Frontview Camera Module																																																									
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2016	Cobalt	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Automatic Transmission																																																									
J	2016	Cobalt	Powertrain	1.4L LKF Engine Control Module Manual Transmission																																																									
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Automatic Transmission																																																									
J	2016	Cobalt	Powertrain	1.5L L2C Engine Control Module Manual Transmission																																																									
J	2016	Cobalt	Powertrain	1.5L L2C Transmission Control Module																																																									
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
J	2016	Cobalt	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
J	2016	Cobalt	Powertrain	1.8L LJ1 Transmission Control Module																																																									
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																									
J	2016	Cobalt	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																									
J	2016	Cobalt	Powertrain	1.8L LMD Transmission Control Module																																																									
J	2016	Cobalt	Chassis	Electronic Brake Control Module																																																									
J	2016	Cobalt	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2016	Cobalt	Body	Body Control Module																																																									
J	2016	Cobalt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2016	Cobalt	Body	Instrument Cluster																																																									
J	2016	Cobalt	Body	Radio Other																																																									
J	2016	Cobalt	Body	Radio (IOB)																																																									
J	2016	Cobalt	Body	Radio (UF7)																																																									
J	2016	Cobalt	Body	HVAC Control Module Heater Only (C41)																																																									
J	2016	Cobalt	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2016	Cobalt	Body	HVAC Control Module Single Zone (C60)																																																									
J	2016	Cobalt	Body	Front Seat Heating Control Module																																																									
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																									
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
J	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																								
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																								
J	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																								
J	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
J	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																								
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
J	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
J	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
J	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
J	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
J	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
J	2016	Cruze	Powertrain	Fuel Injector Control Module																																																								
J	2016	Cruze	Powertrain	Chassis Control Module																																																								
J	2016	Cruze	Chassis	Electronic Brake Control Module																																																								
J	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2016	Cruze	Chassis	Power Steering Control Module																																																								
J	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2016	Cruze	Body	Body Control Module Hatchback																																																								
J	2016	Cruze	Body	Body Control Module Sedan																																																								
J	2016	Cruze	Body	Body Control Module Station Wagon																																																								
J	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2016	Cruze	Body	Passenger Presence Module																																																								
J	2016	Cruze	Body	Instrument Cluster																																																								
J	2016	Cruze	Body	Trailer Interface Control Module																																																								
J	2016	Cruze	Body	Radio Other																																																								
J	2016	Cruze	Body	Radio (UF7)																																																								
J	2016	Cruze	Body	Multimedia Player Interface Module																																																								
J	2016	Cruze	Body	Mobile Telephone Control Module																																																								
J	2016	Cruze	Body	Telematics Communication Interface Control Module																																																								
J	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
J	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																								
J	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																								
J	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																								
J	2016	Cruze	Body	Front Seat Heating Control Module																																																								
J	2016	Cruze	Body	Keyless Entry Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2016	Cruze	Body	Right Side Object Detection Control Module																																																								
J	2016	Cruze	Body	Left Side Object Detection Control Module																																																								
J	2016	Cruze	Body	Parking Assist Control Module																																																								
J	2016	Cruze	Body	Steering Column Lock Control Module																																																								
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.4L L2N Transmission Control Module																																																								
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.4L LDD Transmission Control Module																																																								
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	1.6L LED Transmission Control Module																																																								
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
J	2016	Sonic	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
J	2016	Sonic	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
J	2016	Sonic	Powertrain	Chassis Control Module																																																								
J	2016	Sonic	Powertrain	Fuel Injector Control Module																																																								
J	2016	Sonic	Chassis	Electronic Brake Control Module																																																								
J	2016	Sonic	Chassis	Power Steering Control Module																																																								
J	2016	Sonic	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2016	Sonic	Body	Body Control Module Hatchback																																																								
J	2016	Sonic	Body	Body Control Module Sedan																																																								
J	2016	Sonic	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2016	Sonic	Body	Passenger Presence Module																																																								
J	2016	Sonic	Body	Instrument Cluster																																																								
J	2016	Sonic	Body	Radio Other																																																								
J	2016	Sonic	Body	Radio (UF7)																																																								
J	2016	Sonic	Body	Radio (UH7)																																																								
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 9.7																																																								
J	2016	Sonic	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2016	Sonic	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2016	Sonic	Body	HVAC Control Module Heater Only (C41)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2016	Sonic	Body	HVAC Control Module Single Zone (C60)																																																								
J	2016	Sonic	Body	Front Seat Heating Control Module																																																									
J	2016	Sonic	Body	Parking Assist Control Module																																																									
J	2016	Sonic	Body	Frontview Camera Module																																																									
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
J	2016	Spin	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
J	2016	Spin	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																									
J	2016	Spin	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																									
J	2016	Spin	Powertrain	1.5L L2B Transmission Control Module																																																									
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Automatic Transmission																																																									
J	2016	Spin	Powertrain	1.8L LJ1 Engine Control Module Manual Transmission																																																									
J	2016	Spin	Powertrain	1.8L LJ1 Transmission Control Module																																																									
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Automatic Transmission																																																									
J	2016	Spin	Powertrain	1.8L LMD Engine Control Module Manual Transmission																																																									
J	2016	Spin	Powertrain	1.8L LMD Transmission Control Module																																																									
J	2016	Spin	Chassis	Electronic Brake Control Module																																																									
J	2016	Spin	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2016	Spin	Body	Body Control Module																																																								
J	2016	Spin	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2016	Spin	Body	Instrument Cluster																																																								
J	2016	Spin	Body	Radio																																																								
J	2016	Spin	Body	Telematics Communication Interface Control Module																																																								
J	2016	Spin	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2016	Spin	Body	HVAC Control Module Heater Only (C41)																																																								
J	2016	Spin	Body	HVAC Control Module Single Zone (C60)																																																								
J	2016	Spin	Body	Front Seat Heating Control Module																																																								
J	2016	Spin	Body	Parking Assist Control Module																																																								
K	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																								
K	2006	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																								
K	2006	ALL	Powertrain	Transmission Control Module																																																								
K	2006	ALL	Chassis	Electronic Brake Control Module																																																								
K	2006	ALL	Body	Remote Function Actuation																																																								
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																								
K	2007	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																								
K	2007	ALL	Powertrain	Transmission Control Module																																																								
K	2007	ALL	Chassis	Bosch Electronic Brake Control Module																																																								
K	2007	ALL	Chassis	Teves Electronic Brake Control Module																																																								
K	2007	ALL	Body	Remote Function Actuation																																																								
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																								
K	2008	ALL	Powertrain	(0)1.0L L4 L11 Engine Control Module																																																								
K	2008	ALL	Powertrain	Transmission Control Module																																																								
K	2008	ALL	Chassis	Electronic Brake Control Module																																																								
K	2008	ALL	Body	Remote Function Actuation																																																								
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																								
K	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																								
K	2009	ALL	Powertrain	Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2009	ALL	Chassis	Electronic Brake Control Module																																																								
K	2009	ALL	Body	Remote Function Actuation																																																								
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2010	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																								
K	2010	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																								
K	2010	ALL	Powertrain	Transmission Control Module																																																								
K	2010	ALL	Chassis	Electronic Brake Control Module																																																								
K	2010	ALL	Body	Remote Function Actuation																																																								
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2011	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																								
K	2011	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																								
K	2011	ALL	Powertrain	Transmission Control Module																																																								
K	2011	ALL	Chassis	Electronic Brake Control Module																																																								
K	2011	ALL	Body	Remote Function Actuation																																																								
K	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2012	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																								
K	2012	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																								
K	2012	ALL	Powertrain	Transmission Control Module																																																								
K	2012	ALL	Chassis	Electronic Brake Control Module																																																								
K	2012	ALL	Body	Remote Function Actuation																																																								
K	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2013	Onix	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																								
K	2013	Onix	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																								
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																								
K	2013	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																								
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																								
K	2013	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																								
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2013	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2013	Onix	Powertrain	Transmission Control Module																																																								
K	2013	Onix	Powertrain	Transmission Control Module																																																								
K	2013	Onix	Chassis	Electronic Brake Control Module																																																								
K	2013	Onix	Chassis	Electronic Brake Control Module																																																								
K	2013	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2013	Onix	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2013	Onix	Body	Body Control Module																																																								
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2013	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2013	Onix	Body	Instrument Cluster																																																								
K	2013	Onix	Body	Radio																																																								
K	2013	Onix	Body	Parking Assist Control Module																																																								
K	2013	Onix	Body	Remote Function Actuation																																																								
K	2013	Prisma	Powertrain	Engine Control Module																																																								
K	2013	Prisma	Powertrain	Transmission Control Module																																																								
K	2013	Prisma	Chassis	Electronic Brake Control Module																																																								
K	2013	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2013	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2013	Prisma	Body	Body Control Module																																																								
K	2013	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2013	Prisma	Body	Instrument Cluster																																																								
K	2013	Prisma	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2013	Prisma	Body	Parking Assist Control Module																																																								
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																								
K	2014	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																								
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																								
K	2014	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																								
K	2014	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																								
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2014	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2014	Onix	Powertrain	1.4L LKK Transmission Control Module																																																								
K	2014	Onix	Chassis	Electronic Brake Control Module																																																								
K	2014	Onix	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2014	Onix	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2014	Onix	Body	Body Control Module																																																								
K	2014	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2014	Onix	Body	Instrument Cluster																																																								
K	2014	Onix	Body	Radio																																																								
K	2014	Onix	Body	Parking Assist Control Module																																																								
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																								
K	2014	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																								
K	2014	Prisma	Powertrain	1.0L LKL Transmission Control Module																																																								
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																								
K	2014	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																								
K	2014	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																								
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2014	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2014	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																								
K	2014	Prisma	Chassis	Electronic Brake Control Module																																																								
K	2014	Prisma	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2014	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2014	Prisma	Body	Body Control Module																																																								
K	2014	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2014	Prisma	Body	Instrument Cluster																																																								
K	2014	Prisma	Body	Radio																																																								
K	2014	Prisma	Body	Parking Assist Control Module																																																								
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																								
K	2015	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																								
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																								
K	2015	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																								
K	2015	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																								
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2015	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2015	Onix	Powertrain	1.4L LKK Transmission Control Module																																																								
K	2015	Onix	Chassis	Electronic Brake Control Module																																																								
K	2015	Onix	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2015	Onix	Body	Body Control Module																																																								
K	2015	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2015	Onix	Body	Instrument Cluster																																																								
K	2015	Onix	Body	Radio																																																								
K	2015	Onix	Body	Parking Assist Control Module																																																								
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																								
K	2015	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																								
K	2015	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																								
K	2015	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																								
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2015	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2015	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																								
K	2015	Prisma	Chassis	Electronic Brake Control Module																																																								
K	2015	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2015	Prisma	Body	Body Control Module																																																								
K	2015	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2015	Prisma	Body	Instrument Cluster																																																								
K	2015	Prisma	Body	Radio																																																								
K	2015	Prisma	Body	Parking Assist Control Module																																																								
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																								
K	2016	Onix	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																								
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																								
K	2016	Onix	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																								
K	2016	Onix	Powertrain	1.4L LKJ Transmission Control Module																																																								
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2016	Onix	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2016	Onix	Powertrain	1.4L LKK Transmission Control Module																																																								
K	2016	Onix	Chassis	Electronic Brake Control Module																																																								
K	2016	Onix	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2016	Onix	Body	Body Control Module																																																								
K	2016	Onix	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2016	Onix	Body	Instrument Cluster																																																								
K	2016	Onix	Body	Radio																																																								
K	2016	Onix	Body	Parking Assist Control Module																																																								
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Automatic Transmission																																																								
K	2016	Prisma	Powertrain	1.0L LKL Engine Control Module Manual Transmission																																																								
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Automatic Transmission																																																								
K	2016	Prisma	Powertrain	1.4L LKJ Engine Control Module Manual Transmission																																																								
K	2016	Prisma	Powertrain	1.4L LKJ Transmission Control Module																																																								
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Automatic Transmission																																																								
K	2016	Prisma	Powertrain	1.4L LKK Engine Control Module Manual Transmission																																																								
K	2016	Prisma	Powertrain	1.4L LKK Transmission Control Module																																																								
K	2016	Prisma	Chassis	Electronic Brake Control Module																																																								
K	2016	Prisma	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2016	Prisma	Body	Body Control Module																																																								
K	2016	Prisma	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2016	Prisma	Body	Instrument Cluster																																																								
K	2016	Prisma	Body	Radio																																																								
K	2016	Prisma	Body	HVAC Control Module																																																								
K	2016	Prisma	Body	Front Seat Heating Control Module																																																								
K	2016	Prisma	Body	Parking Assist Control Module																																																								
L	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
L	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
L	2004	ALL	Powertrain	Transmission Control Module																																																								
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																								
L	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																								
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2004	ALL	Body	ISU																																																								
L	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
L	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
L	2005	ALL	Powertrain	Transmission Control Module																																																								
L	2005	ALL	Chassis	Anti-lock Brake System																																																								
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2005	ALL	Body	ISU																																																								
L	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
L	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
L	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																								
L	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																								
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2006	ALL	Body	ISU																																																								
L	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
L	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
L	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																								
L	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																								
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																								
L	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector																																																								
L	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
L	2007	ALL	Chassis	Electronic Brake Control Module																																																								
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2007	ALL	Body	ISU																																																								
L	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
L	2008	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																								
L	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																								
L	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
L	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
L	2008	ALL	Chassis	Electronic Brake Control Module																																																								
L	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2008	ALL	Body	ISU																																																								
L	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
L	2009	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																								
L	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																								
L	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
L	2009	ALL	Chassis	Electronic Brake Control Module																																																								
L	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2009	ALL	Body	ISU																																																								
L	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
L	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																								
L	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																								
L	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																								
L	2010	ALL	Chassis	Electronic Brake Control Module																																																								
L	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2010	ALL	Body	ISU																																																								
L	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
L	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																									
L	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																										
L	2011	ALL	Chassis	Electronic Brake Control Module																																																										
L	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2011	ALL	Body	ISU																																																										
M	2004	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2004	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2004	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2004	ALL	Chassis	Anti-lock Brake System																																																										
M	2004	ALL	Body	Remote Function Actuation																																																										
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2005	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2005	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2005	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2005	ALL	Chassis	Anti-lock Brake System																																																										
M	2005	ALL	Body	Remote Function Actuation																																																										
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2006	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2006	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2006	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2006	ALL	Chassis	Anti-lock Brake System																																																										
M	2006	ALL	Body	Remote Function Actuation																																																										
M	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2007	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2007	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2007	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2007	ALL	Chassis	Anti-lock Brake System																																																										
M	2007	ALL	Body	Remote Function Actuation																																																										
M	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2008	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2008	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2008	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2008	ALL	Chassis	Anti-lock Brake System																																																										
M	2008	ALL	Body	Remote Function Actuation																																																										
M	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2009	ALL	Powertrain	(4)0.8L L3 LBF Engine Control Module																																																										
M	2009	ALL	Powertrain	(0)1.0L L4 LA2 Engine Control Module																																																										
M	2009	ALL	Powertrain	(J)1.0L L4 LA2 Engine Control Module																																																										
M	2009	ALL	Chassis	Anti-lock Brake System																																																										
M	2009	ALL	Body	Remote Function Actuation																																																										
M	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2010	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2010	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																										
M	2010	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																										
M	2010	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																										
M	2010	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2010	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2010	Spark	Powertrain	Transmission Control Module																																																										
M	2010	Spark	Chassis	Electronic Brake Control Module																																																										
M	2010	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2010	Spark	Chassis	Electric Power Steering Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
M	2010	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2010	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2010	Spark	Body	Passenger Presence Module																																																								
M	2010	Spark	Body	Instrument Cluster																																																								
M	2011	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																								
M	2011	Caprice	Powertrain	Transmission Control Module																																																								
M	2011	Caprice	Powertrain	Fuel Pump Control Module																																																								
M	2011	Caprice	Chassis	Electronic Brake Control Module																																																								
M	2011	Caprice	Body	Body Control Module																																																								
M	2011	Caprice	Body	HVAC Control Module																																																								
M	2011	Caprice	Body	Instrument Panel Cluster																																																								
M	2011	Caprice	Body	Passenger Presence System																																																								
M	2011	Caprice	Body	Radio																																																								
M	2011	Caprice	Body	Remote Control Door Lock Receiver																																																								
M	2011	Caprice	Body	Supplemental Inflatable Restraint																																																								
M	2011	Caprice	Body	Theft Deterrent Module																																																								
M	2011	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
M	2011	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
M	2011	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
M	2011	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
M	2011	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																								
M	2011	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																								
M	2011	Spark	Powertrain	Transmission Control Module																																																								
M	2011	Spark	Chassis	Electronic Brake Control Module																																																								
M	2011	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
M	2011	Spark	Chassis	Electric Power Steering Control Module																																																								
M	2011	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2011	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2011	Spark	Body	Passenger Presence Module																																																								
M	2011	Spark	Body	Instrument Cluster																																																								
M	2012	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																								
M	2012	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																								
M	2012	Caprice	Powertrain	Transmission Control Module																																																								
M	2012	Caprice	Powertrain	Fuel Pump Control Module																																																								
M	2012	Caprice	Chassis	Electronic Brake Control Module																																																								
M	2012	Caprice	Body	Body Control Module																																																								
M	2012	Caprice	Body	HVAC Control Module																																																								
M	2012	Caprice	Body	Instrument Panel Cluster																																																								
M	2012	Caprice	Body	Passenger Presence System																																																								
M	2012	Caprice	Body	Radio																																																								
M	2012	Caprice	Body	Remote Control Door Lock Receiver																																																								
M	2012	Caprice	Body	Supplemental Inflatable Restraint																																																								
M	2012	Caprice	Body	Theft Deterrent Module																																																								
M	2012	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
M	2012	Spark	Powertrain	1.0L LCP Fuel Injector Control Module																																																								
M	2012	Spark	Powertrain	1.0L LEB Engine Automatic Control Module																																																								
M	2012	Spark	Powertrain	1.0L LEB Engine Manual Control Module																																																								
M	2012	Spark	Powertrain	(1) 1.0L LMT Engine Control Module																																																								
M	2012	Spark	Powertrain	1.19L LC5 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
M	2012	Spark	Powertrain	1.2L L2E Engine Control Module																																																								
M	2012	Spark	Powertrain	(D) 1.2L LMU Engine Control Module																																																								
M	2012	Spark	Powertrain	Transmission Control Module																																																								
M	2012	Spark	Chassis	Electronic Brake Control Module																																																								
M	2012	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
M	2012	Spark	Chassis	Electric Power Steering Control Module																																																								
M	2012	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2012	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2012	Spark	Body	Passenger Presence Module																																																								
M	2012	Spark	Body	Instrument Cluster																																																								
M	2013	Caprice	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																								
M	2013	Caprice	Powertrain	(2)6.0L V8 L77 Engine Control Module																																																								
M	2013	Caprice	Powertrain	Transmission Control Module																																																								
M	2013	Caprice	Powertrain	Fuel Pump Control Module																																																								
M	2013	Caprice	Chassis	Electronic Brake Control Module																																																								
M	2013	Caprice	Body	Body Control Module																																																								
M	2013	Caprice	Body	HVAC Control Module																																																								
M	2013	Caprice	Body	Instrument Panel Cluster																																																								
M	2013	Caprice	Body	Passenger Presence System																																																								
M	2013	Caprice	Body	Radio																																																								
M	2013	Caprice	Body	Remote Control Door Lock Receiver																																																								
M	2013	Caprice	Body	Supplemental Inflatable Restraint																																																								
M	2013	Caprice	Body	Theft Deterrent Module																																																								
M	2013	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
M	2013	Spark	Powertrain	1.0L LCP Transmission Control Module																																																								
M	2013	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
M	2013	Spark	Powertrain	1.0L LMT Transmission Control Module																																																								
M	2013	Spark	Powertrain	1.19L LC5 Engine Control Module																																																								
M	2013	Spark	Powertrain	1.19L LC5 Transmission Control Module																																																								
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																								
M	2013	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																								
M	2013	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																								
M	2013	Spark	Powertrain	1.2L L2E Engine Control Module																																																								
M	2013	Spark	Powertrain	1.2L L2E Transmission Control Module																																																								
M	2013	Spark	Powertrain	1.2L LKY Engine Control Module																																																								
M	2013	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
M	2013	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
M	2013	Spark	Powertrain	Fuel Injector Control Module																																																								
M	2013	Spark	Chassis	Electronic Brake Control Module																																																								
M	2013	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
M	2013	Spark	Chassis	Power Steering Control Module																																																								
M	2013	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
M	2013	Spark	Body	Body Control Module																																																								
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2013	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2013	Spark	Body	Passenger Presence Module																																																								
M	2013	Spark	Body	Instrument Cluster																																																								
M	2013	Spark	Body	Radio																																																								
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 9																																																								
M	2013	Spark	Body	Telematics Communication Interface Control Module Version 10																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
M	2014	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
M	2014	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LA2 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2014	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2014	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2014	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2014	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2014	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2014	Spark	Chassis	Power Steering Control Module																																																										
M	2014	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2014	Spark	Body	Body Control Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark	Body	Passenger Presence Module																																																										
M	2014	Spark	Body	Instrument Cluster																																																									
M	2014	Spark	Body	Radio																																																									
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2014	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark	Body	Keyless Entry Control Module																																																										
M	2014	Spark EV	Powertrain	Engine Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2014	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
M	2014	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2014	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										
M	2014	Spark EV	Chassis	Electronic Brake Control Module																																																										
M	2014	Spark EV	Chassis	Parking Brake Control Module																																																										
M	2014	Spark EV	Chassis	Power Steering Control Module																																																										
M	2014	Spark EV	Body	Body Control Module																																																										
M	2014	Spark EV	Body	Pedestrian Alert Sound Control Module																																																										
M	2014	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2014	Spark EV	Body	Passenger Presence Module																																																										
M	2014	Spark EV	Body	Instrument Cluster																																																										
M	2014	Spark EV	Body	Radio																																																									
M	2014	Spark EV	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2014	Spark EV	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
M	2014	Spark EV	Body	Electric A/C Compressor Control Module																																																									
M	2014	Spark EV	Body	Coolant Heater Control Module																																																										
M	2014	Spark EV	Body	Keyless Entry Control Module																																																										
M	2014	Spark EV	Body	Battery Charger Control Module																																																										
M	2014	Spark EV	Body	DC Charging Control Module																																																										
M	2014	Spark EV	Body	Battery Energy Control Module																																																										
M	2015	Matiz	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2015	Matiz	Chassis	Electronic Brake Control Module																																																										
M	2015	Matiz	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Matiz	Body	Keyless Entry Control Module																																																										
M	2015	Spark	Powertrain	0.8L LBF Engine Control Module																																																										
M	2015	Spark	Powertrain	0.8L LBF Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.0L LA2 Engine Control Module																																																										
M	2015	Spark	Powertrain	1.0L LCP Engine Control Module																																																										
M	2015	Spark	Powertrain	1.0L LCP Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Automatic Transmission																																																										
M	2015	Spark	Powertrain	1.0L LFM Engine Control Module Manual Transmission																																																										
M	2015	Spark	Powertrain	1.0L LFM Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.0L LMT Engine Control Module																																																										
M	2015	Spark	Powertrain	1.0L LMT Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Automatic Transmission																																																										
M	2015	Spark	Powertrain	(9) 1.2L LL0 Engine Control Module Manual Transmission																																																										
M	2015	Spark	Powertrain	(9) 1.2L LL0 Transmission Control Module																																																										
M	2015	Spark	Powertrain	1.2L LKY Engine Control Module																																																										
M	2015	Spark	Powertrain	1.2L LMU Engine Control Module																																																										
M	2015	Spark	Powertrain	1.2L LMU Transmission Control Module																																																										
M	2015	Spark	Powertrain	Fuel Injector Control Module																																																										
M	2015	Spark	Chassis	Electronic Brake Control Module																																																										
M	2015	Spark	Chassis	Electronic Brake Control Module																																																										
M	2015	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																										
M	2015	Spark	Chassis	Power Steering Control Module																																																										
M	2015	Spark	Chassis	Steering Wheel Angle Sensor Module																																																										
M	2015	Spark	Body	Body Control Module																																																										
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	Spark	Body	Passenger Presence Module																																																										
M	2015	Spark	Body	Instrument Cluster																																																										
M	2015	Spark	Body	Instrument Cluster																																																										
M	2015	Spark	Body	Tire Pressure Indicator Module																																																										
M	2015	Spark	Body	Radio																																																										
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 9																																																										
M	2015	Spark	Body	Telematics Communication Interface Control Module Version 10																																																										
M	2015	Spark	Body	Keyless Entry Control Module																																																										
M	2015	Spark EV	Powertrain	Engine Control Module																																																										
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																										
M	2015	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																										
M	2015	Spark EV	Powertrain	Drive Motor Control Module																																																										
M	2015	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
M	2015	Spark EV	Chassis	Electronic Brake Control Module																																																								
M	2015	Spark EV	Chassis	Parking Brake Control Module																																																								
M	2015	Spark EV	Chassis	Power Steering Control Module																																																								
M	2015	Spark EV	Body	Body Control Module																																																								
M	2015	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
M	2015	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2015	Spark EV	Body	Passenger Presence Module																																																								
M	2015	Spark EV	Body	Instrument Cluster																																																								
M	2015	Spark EV	Body	Radio																																																								
M	2015	Spark EV	Body	HVAC Control Module																																																								
M	2015	Spark EV	Body	Electric A/C Compressor Control Module																																																								
M	2015	Spark EV	Body	Coolant Heater Control Module																																																								
M	2015	Spark EV	Body	Keyless Entry Control Module																																																								
M	2015	Spark EV	Body	Battery Charger Control Module																																																								
M	2015	Spark EV	Body	DC Charging Control Module																																																								
M	2015	Spark EV	Body	Battery Energy Control Module																																																								
M	2016	Spark	Powertrain	0.8L LBF Engine Control Module																																																								
M	2016	Spark	Powertrain	0.8L LBF Fuel Injector Control Module																																																								
M	2016	Spark	Powertrain	0.8L LBF Transmission Control Module																																																								
M	2016	Spark	Powertrain	1.0L LA2 Engine Control Module																																																								
M	2016	Spark	Powertrain	1.0L LA2 Fuel Injector Control Module																																																								
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Automatic Transmission																																																								
M	2016	Spark	Powertrain	1.0L L5Q Engine Control Module Manual Transmission																																																								
M	2016	Spark	Powertrain	1.0L LCP Engine Control Module																																																								
M	2016	Spark	Powertrain	1.0L LCP Transmission Control Module																																																								
M	2016	Spark	Powertrain	1.0L LMT Engine Control Module																																																								
M	2016	Spark	Powertrain	1.0L LMT Transmission Control Module																																																								
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
M	2016	Spark	Powertrain	1.2L LMU Fuel Injector Control Module																																																								
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Automatic Transmission																																																								
M	2016	Spark	Powertrain	1.2L LL0 Engine Control Module Manual Transmission																																																								
M	2016	Spark	Powertrain	1.2L LL0 Transmission Control Module																																																								
M	2016	Spark	Powertrain	1.2L LKY Engine Control Module																																																								
M	2016	Spark	Powertrain	1.2L LMU Engine Control Module																																																								
M	2016	Spark	Powertrain	1.2L LMU Transmission Control Module																																																								
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Automatic Transmission																																																								
M	2016	Spark	Powertrain	(A) 1.4L LV7 Engine Control Module Manual Transmission																																																								
M	2016	Spark	Powertrain	Fuel Injector Control Module																																																								
M	2016	Spark	Chassis	Electronic Brake Control Module																																																								
M	2016	Spark	Chassis	Electronic Brake Control Module																																																								
M	2016	Spark	Chassis	Multi-Axis Acceleration Sensor Module																																																								
M	2016	Spark	Chassis	Power Steering Control Module																																																								
M	2016	Spark	Chassis	Steering Wheel Angle Sensor Module																																																								
M	2016	Spark	Body	Body Control Module																																																								
M	2016	Spark	Body	Body Control Module																																																								
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2016	Spark	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2016	Spark	Body	Instrument Cluster																																																								
M	2016	Spark	Body	Instrument Cluster																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
M	2016	Spark	Body	Radio																																																								
M	2016	Spark	Body	Telematics Communication Interface Control Module																																																								
M	2016	Spark	Body	Keyless Entry Control Module																																																								
M	2016	Spark EV	Powertrain	Engine Control Module																																																								
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module																																																								
M	2016	Spark EV	Powertrain	Hybrid Powertrain Control Module 2																																																								
M	2016	Spark EV	Powertrain	Drive Motor Control Module																																																								
M	2016	Spark EV	Powertrain	Auxiliary Transmission Fluid Pump																																																								
M	2016	Spark EV	Chassis	Electronic Brake Control Module																																																								
M	2016	Spark EV	Chassis	Parking Brake Control Module																																																								
M	2016	Spark EV	Chassis	Power Steering Control Module																																																								
M	2016	Spark EV	Body	Body Control Module																																																								
M	2016	Spark EV	Body	Pedestrian Alert Sound Control Module																																																								
M	2016	Spark EV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
M	2016	Spark EV	Body	Passenger Presence Module																																																								
M	2016	Spark EV	Body	Instrument Cluster																																																								
M	2016	Spark EV	Body	Radio																																																								
M	2016	Spark EV	Body	Telematics Communication Interface Control Module																																																								
M	2016	Spark EV	Body	HVAC Control Module																																																								
M	2016	Spark EV	Body	Electric A/C Compressor Control Module																																																								
M	2016	Spark EV	Body	Coolant Heater Control Module																																																								
M	2016	Spark EV	Body	Keyless Entry Control Module																																																								
M	2016	Spark EV	Body	Frontview Camera Module																																																								
M	2016	Spark EV	Body	Battery Charger Control Module																																																								
M	2016	Spark EV	Body	DC Charging Control Module																																																								
M	2016	Spark EV	Body	Battery Energy Control Module																																																								
N	2004	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
N	2004	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
N	2004	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
N	2004	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																								
N	2004	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
N	2004	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2004	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																								
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																								
N	2004	Optra	Chassis	Anti-lock Brake System Traction Control No																																																								
N	2004	Optra	Body	Remote Function Actuation																																																								
N	2004	Optra	Body	Supplemental Inflatable Restraint																																																								
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
N	2004	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
N	2004	Classic	Chassis	Anti-lock Brake System																																																								
N	2004	Classic	Body	Body Control Module																																																								
N	2004	Classic	Body	Radio																																																								
N	2004	Classic	Body	Remote Function Actuation																																																								
N	2004	Classic	Body	Supplemental Inflatable Restraint																																																								
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																								
N	2004	Alero (Export)	Powertrain	(E)3.4L V6 LA1 Transmission Control Module																																																								
N	2004	Alero (Export)	Chassis	Anti-lock Brake System																																																								
N	2004	Alero (Export)	Body	Body Control Module																																																								
N	2004	Alero (Export)	Body	Instrument Panel Cluster																																																								
N	2004	Alero (Export)	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
N	2004	Alero (Export)	Body	Supplemental Inflatable Restraint																																																								
N	2004	Alero (Export)	Body	Vehicle Theft Deterrent																																																								
N	2005	Optra	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
N	2005	Optra	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
N	2005	Optra	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
N	2005	Optra	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																								
N	2005	Optra	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
N	2005	Optra	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2005	Optra	Powertrain	MFA Transmission Control Module 4 Speed																																																								
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control Yes																																																								
N	2005	Optra	Chassis	Anti-lock Brake System Traction Control No																																																								
N	2005	Optra	Body	Remote Function Actuation																																																								
N	2005	Optra	Body	Supplemental Inflatable Restraint																																																								
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
N	2005	Classic	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
N	2005	Classic	Chassis	Anti-lock Brake System																																																								
N	2005	Classic	Body	Body Control Module																																																								
N	2005	Classic	Body	Radio																																																								
N	2005	Classic	Body	Remote Function Actuation																																																								
N	2005	Classic	Body	Supplemental Inflatable Restraint																																																								
N	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
N	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
N	2006	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
N	2006	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
N	2006	ALL	Powertrain	(8)1.8L L4 L79 Engine Control Module																																																								
N	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
N	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2006	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
N	2006	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																								
N	2006	ALL	Body	Remote Function Actuation																																																								
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
N	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
N	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
N	2007	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
N	2007	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																								
N	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
N	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2007	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
N	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control Yes																																																								
N	2007	ALL	Chassis	Bosch Electronic Brake Control Module Traction Control No																																																								
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control Yes																																																								
N	2007	ALL	Chassis	Teves Electronic Brake Control Module Traction Control No																																																								
N	2007	ALL	Chassis	Tire Pressure Monitor																																																								
N	2007	ALL	Body	Remote Function Actuation																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
N	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
N	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
N	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																								
N	2008	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
N	2008	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
N	2008	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																								
N	2008	ALL	Powertrain	(D)2.0L L4 LMN Engine Control Module																																																								
N	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
N	2008	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																								
N	2008	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2008	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
N	2008	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
N	2008	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																								
N	2008	ALL	Chassis	Tire Pressure Monitor																																																								
N	2008	ALL	Body	Remote Function Actuation																																																								
N	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
N	2009	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
N	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																								
N	2009	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
N	2009	ALL	Powertrain	(3)1.8L L4 L79 Engine Control Module																																																								
N	2009	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																								
N	2009	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
N	2009	ALL	Powertrain	M92 Transmission Control Module 4 Speed																																																								
N	2009	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2009	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
N	2009	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
N	2009	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																								
N	2009	ALL	Chassis	Tire Pressure Monitor																																																								
N	2009	ALL	Body	Remote Function Actuation																																																								
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2010	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
N	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																								
N	2010	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																								
N	2010	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																								
N	2010	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
N	2010	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
N	2010	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																								
N	2010	ALL	Powertrain	Transmission Control Module 5 Speed																																																								
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																								
N	2010	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																								
N	2010	ALL	Chassis	Tire Pressure Monitor																																																								
N	2010	ALL	Body	Remote Function Actuation																																																								
N	2010	ALL	Body	Remote Function Actuation																																																								
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
N	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
N	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
N	2011	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																									
N	2011	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																									
N	2011	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
N	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
N	2011	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																									
N	2011	ALL	Powertrain	Transmission Control Module 5 Speed																																																									
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
N	2011	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																									
N	2011	ALL	Chassis	Tire Pressure Monitor																																																									
N	2011	ALL	Body	Remote Function Actuation																																																									
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2012	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
N	2012	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
N	2012	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																									
N	2012	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																									
N	2012	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
N	2012	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																									
N	2012	ALL	Powertrain	Transmission Control Module 5 Speed																																																									
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
N	2012	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																									
N	2012	ALL	Chassis	Tire Pressure Monitor																																																									
N	2012	ALL	Body	Remote Function Actuation																																																									
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2013	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
N	2013	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
N	2013	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																									
N	2013	ALL	Powertrain	(U)2.0L L4 LMN Engine Control Module																																																									
N	2013	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
N	2013	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																									
N	2013	ALL	Powertrain	Transmission Control Module 5 Speed																																																									
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control Yes																																																									
N	2013	ALL	Chassis	Electronic Brake Control Module Traction Control No																																																									
N	2013	ALL	Chassis	Tire Pressure Monitor																																																									
N	2013	ALL	Body	Remote Function Actuation																																																									
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
N	2014	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
N	2014	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																									
N	2014	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																									
N	2014	Caprice	Powertrain	(2) 6.0L L77 Chassis Control Module																																																									
N	2014	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																									
N	2014	Caprice	Chassis	Electronic Brake Control Module																																																									
N	2014	Caprice	Chassis	Parking Brake Control Module																																																									
N	2014	Caprice	Chassis	Power Steering Control Module																																																									
N	2014	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2014	Caprice	Body	Body Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
N	2014	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2014	Caprice	Body	Passenger Presence Module																																																										
N	2014	Caprice	Body	Instrument Cluster																																																										
N	2014	Caprice	Body	Radio Controls																																																										
N	2014	Caprice	Body	HVAC Controls																																																										
N	2014	Caprice	Body	Headlamp Control Module																																																										
N	2014	Caprice	Body	Trailer Interface Control Module																																																										
N	2014	Caprice	Body	Radio																																																										
N	2014	Caprice	Body	HVAC Control Module																																																										
N	2014	Caprice	Body	Parking Assist Control Module																																																										
N	2014	Caprice	Body	Frontview Camera Module																																																										
N	2014	Caprice	Body	Steering Column Lock Control Module																																																										
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
N	2015	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
N	2015	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
N	2015	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
N	2015	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
N	2015	Caprice	Powertrain	Fuel Injector Control Module																																																										
N	2015	Caprice	Chassis	Electronic Brake Control Module																																																										
N	2015	Caprice	Chassis	Parking Brake Control Module																																																										
N	2015	Caprice	Chassis	Power Steering Control Module																																																										
N	2015	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2015	Caprice	Chassis	Suspension Control Module																																																										
N	2015	Caprice	Body	Body Control Module																																																										
N	2015	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2015	Caprice	Body	Passenger Presence Module																																																										
N	2015	Caprice	Body	Instrument Cluster																																																										
N	2015	Caprice	Body	Head-Up Display Module																																																										
N	2015	Caprice	Body	Radio Controls																																																										
N	2015	Caprice	Body	HVAC Controls																																																										
N	2015	Caprice	Body	Headlamp Control Module																																																										
N	2015	Caprice	Body	Trailer Interface Control Module																																																										
N	2015	Caprice	Body	Radio																																																										
N	2015	Caprice	Body	Telematics Communication Interface Control Module																																																										
N	2015	Caprice	Body	HVAC Control Module																																																										
N	2015	Caprice	Body	Right Side Object Detection Control Module																																																										
N	2015	Caprice	Body	Left Side Object Detection Control Module																																																										
N	2015	Caprice	Body	Parking Assist Control Module																																																										
N	2015	Caprice	Body	Frontview Camera Module																																																										
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
N	2016	Caprice	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
N	2016	Caprice	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																										
N	2016	Caprice	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																										
N	2016	Caprice	Powertrain	(2) 6.0L L77 Transmission Control Module																																																										
N	2016	Caprice	Powertrain	Fuel Injector Control Module																																																										
N	2016	Caprice	Chassis	Electronic Brake Control Module																																																										
N	2016	Caprice	Chassis	Parking Brake Control Module																																																										
N	2016	Caprice	Chassis	Power Steering Control Module																																																										
N	2016	Caprice	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
N	2016	Caprice	Chassis	Suspension Control Module																																																								
N	2016	Caprice	Body	Body Control Module																																																								
N	2016	Caprice	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
N	2016	Caprice	Body	Passenger Presence Module																																																								
N	2016	Caprice	Body	Instrument Cluster																																																								
N	2016	Caprice	Body	Head-Up Display Module																																																								
N	2016	Caprice	Body	Radio Controls																																																								
N	2016	Caprice	Body	HVAC Controls																																																								
N	2016	Caprice	Body	Trailer Interface Control Module																																																								
N	2016	Caprice	Body	Radio																																																								
N	2016	Caprice	Body	Telematics Communication Interface Control Module																																																								
N	2016	Caprice	Body	HVAC Control Module																																																								
N	2016	Caprice	Body	Seat Memory Control Module - Driver																																																								
N	2016	Caprice	Body	Right Side Object Detection Control Module																																																								
N	2016	Caprice	Body	Left Side Object Detection Control Module																																																								
N	2016	Caprice	Body	Parking Assist Control Module																																																								
N	2016	Caprice	Body	Frontview Camera Module																																																								
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Automatic Transmission																																																								
P	2010	Cruze	Powertrain	(6) 1.6L LXT Engine Control Module Manual Transmission																																																								
P	2010	Cruze	Powertrain	(6) 1.6L LXT Transmission Control Module																																																								
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Automatic Transmission																																																								
P	2010	Cruze	Powertrain	(E) 1.6L LXV Engine Edge Manual Transmission																																																								
P	2010	Cruze	Powertrain	(E) 1.6L LXV Transmission Control Module																																																								
P	2010	Cruze	Powertrain	1.8L 2HO Engine Automatic Transmission																																																								
P	2010	Cruze	Powertrain	1.8L 2HO Engine Manual Transmission																																																								
P	2010	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																								
P	2010	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																								
P	2010	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																								
P	2010	Cruze	Chassis	Electronic Brake Control Module																																																								
P	2010	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2010	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2010	Cruze	Body	Body Control Module																																																								
P	2010	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2010	Cruze	Body	Passenger Presence Module																																																								
P	2010	Cruze	Body	Instrument Cluster																																																								
P	2010	Cruze	Body	Trailer Interface Control Module																																																								
P	2010	Cruze	Body	Radio																																																								
P	2010	Cruze	Body	Multimedia Player Interface Module																																																								
P	2010	Cruze	Body	Mobile Telephone Control Module																																																								
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
P	2010	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
P	2010	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																								
P	2010	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																								
P	2010	Cruze	Body	Keyless Entry Control Module																																																								
P	2010	Cruze	Body	Parking Assist Control Module																																																								
P	2010	Cruze	Body	Steering Column Lock Control Module																																																								
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Fuel Pump Control Module																																																								
P	2011	Cruze	Powertrain	(9) 1.4L LUJ Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																									
P	2011	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																									
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																									
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																									
P	2011	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																									
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																									
P	2011	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																									
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																									
P	2011	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																									
P	2011	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
P	2011	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																									
P	2011	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	2.0L LLW Engine Control Module Manual Transmission																																																									
P	2011	Cruze	Powertrain	2.0L LLW Transmission Control Module																																																									
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2011	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2011	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2011	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2011	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2011	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2011	Cruze	Body	Body Control Module																																																								
P	2011	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2011	Cruze	Body	Passenger Presence Module																																																									
P	2011	Cruze	Body	Instrument Cluster																																																								
P	2011	Cruze	Body	Trailer Interface Control Module																																																									
P	2011	Cruze	Body	Radio																																																								
P	2011	Cruze	Body	Multimedia Player Interface Module																																																									
P	2011	Cruze	Body	Mobile Telephone Control Module																																																									
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2011	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
P	2011	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
P	2011	Cruze	Body	Keyless Entry Control Module																																																									
P	2011	Cruze	Body	Parking Assist Control Module																																																									
P	2011	Cruze	Body	Steering Column Lock Control Module																																																									
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Fuel Pump Control Module																																																									
P	2012	Cruze	Powertrain	(C) 1.4L LUJ Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
P	2012	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.6L LDE Engine Edge Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.6L LDE Engine Face Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.6L LDE Transmission Control Module																																																									
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.8L 2HO Engine Edge Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.8L 2HO Engine Face Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Control Module																																																									
P	2012	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																									
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(R) 2.0L LLW Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Engine Control Module Manual Transmission																																																									
P	2012	Cruze	Powertrain	(Y) 2.0L LNP Transmission Control Module																																																									
P	2012	Cruze	Chassis	Electronic Brake Control Module																																																									
P	2012	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2012	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2012	Cruze	Body	Body Control Module Hatchback																																																									
P	2012	Cruze	Body	Body Control Module Sedan																																																									
P	2012	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2012	Cruze	Body	Passenger Presence Module																																																									
P	2012	Cruze	Body	Instrument Cluster																																																									
P	2012	Cruze	Body	Trailer Interface Control Module																																																									
P	2012	Cruze	Body	Radio																																																									
P	2012	Cruze	Body	Multimedia Player Interface Module																																																									
P	2012	Cruze	Body	Mobile Telephone Control Module																																																									
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2012	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
P	2012	Cruze	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
P	2012	Cruze	Body	Keyless Entry Control Module																																																									
P	2012	Cruze	Body	Parking Assist Control Module																																																									
P	2012	Cruze	Body	Steering Column Lock Control Module																																																									
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
P	2013	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
P	2013	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																								
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																								
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																								
P	2013	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2013	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																								
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																								
P	2013	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																								
P	2013	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																								
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																								
P	2013	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2013	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																								
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
P	2013	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2013	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2013	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2013	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2013	Cruze	Chassis	Electronic Brake Control Module																																																								
P	2013	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2013	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2013	Cruze	Body	Body Control Module Hatchback																																																								
P	2013	Cruze	Body	Body Control Module Sedan																																																								
P	2013	Cruze	Body	Body Control Module Station Wagon																																																								
P	2013	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2013	Cruze	Body	Passenger Presence Module																																																								
P	2013	Cruze	Body	Instrument Cluster																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
P	2013	Cruze	Body	Trailer Interface Control Module																																																								
P	2013	Cruze	Body	Radio																																																								
P	2013	Cruze	Body	Digital Radio Receiver Control Module																																																								
P	2013	Cruze	Body	Multimedia Player Interface Module																																																								
P	2013	Cruze	Body	Mobile Telephone Control Module																																																								
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
P	2013	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
P	2013	Cruze	Body	HVAC Control Module Auto Single (C68)																																																								
P	2013	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																								
P	2013	Cruze	Body	HVAC Control Module Manual Single (C67)																																																								
P	2013	Cruze	Body	Front Seat Heating Control Module																																																								
P	2013	Cruze	Body	Keyless Entry Control Module																																																								
P	2013	Cruze	Body	Right Side Object Detection Control Module																																																								
P	2013	Cruze	Body	Left Side Object Detection Control Module																																																								
P	2013	Cruze	Body	Parking Assist Control Module																																																								
P	2013	Cruze	Body	Steering Column Lock Control Module																																																								
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																								
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																								
P	2014	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																								
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																								
P	2014	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																								
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																								
P	2014	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																								
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2014	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2014	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																								
P	2014	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																								
P	2014	Cruze	Powertrain	Fuel Injector Control Module																																																								
P	2014	Cruze	Chassis	Electronic Brake Control Module																																																								
P	2014	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2014	Cruze	Chassis	Power Steering Control Module																																																								
P	2014	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2014	Cruze	Body	Body Control Module Hatchback																																																								
P	2014	Cruze	Body	Body Control Module Sedan																																																								
P	2014	Cruze	Body	Body Control Module Station Wagon																																																								
P	2014	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2014	Cruze	Body	Passenger Presence Module																																																								
P	2014	Cruze	Body	Instrument Cluster																																																								
P	2014	Cruze	Body	Trailer Interface Control Module																																																								
P	2014	Cruze	Body	Radio																																																								
P	2014	Cruze	Body	Digital Radio Receiver Control Module																																																								
P	2014	Cruze	Body	Multimedia Player Interface Module																																																								
P	2014	Cruze	Body	Mobile Telephone Control Module																																																								
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
P	2014	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
P	2014	Cruze	Body	HVAC Control Module Auto Single (C68)																																																								
P	2014	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																								
P	2014	Cruze	Body	HVAC Control Module Manual Single (C67)																																																								
P	2014	Cruze	Body	Front Seat Heating Control Module																																																								
P	2014	Cruze	Body	Keyless Entry Control Module																																																								
P	2014	Cruze	Body	Right Side Object Detection Control Module																																																								
P	2014	Cruze	Body	Left Side Object Detection Control Module																																																								
P	2014	Cruze	Body	Parking Assist Control Module																																																								
P	2014	Cruze	Body	Steering Column Lock Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.6L LLU Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.6L LLU Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.6L LVM Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.7L LKR Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	(G) 1.8L LWE Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2015	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2015	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Engine Control Module																																																								
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump																																																								
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Fuel Pump Version Fuel Pump and Active Grille Air Shutter																																																								
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Glow Plug Control Module																																																								
P	2015	Cruze	Powertrain	(Z) 2.0L LUZ Transmission Control Module																																																								
P	2015	Cruze	Powertrain	Fuel Injector Control Module																																																								
P	2015	Cruze	Chassis	Electronic Brake Control Module																																																								
P	2015	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2015	Cruze	Chassis	Power Steering Control Module																																																								
P	2015	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2015	Cruze	Body	Body Control Module Hatchback																																																								
P	2015	Cruze	Body	Body Control Module Sedan																																																								
P	2015	Cruze	Body	Body Control Module Station Wagon																																																								
P	2015	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2015	Cruze	Body	Passenger Presence Module																																																								
P	2015	Cruze	Body	Instrument Cluster																																																								
P	2015	Cruze	Body	Trailer Interface Control Module																																																								
P	2015	Cruze	Body	Radio																																																								
P	2015	Cruze	Body	Digital Radio Receiver Control Module																																																								
P	2015	Cruze	Body	Multimedia Player Interface Module																																																								
P	2015	Cruze	Body	Mobile Telephone Control Module																																																								
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 9																																																								
P	2015	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
P	2015	Cruze	Body	HVAC Control Module Auto Single (C68)																																																								
P	2015	Cruze	Body	HVAC Control Module Manual Heater Only (C42)																																																								
P	2015	Cruze	Body	HVAC Control Module Manual Single (C67)																																																								
P	2015	Cruze	Body	Front Seat Heating Control Module																																																								
P	2015	Cruze	Body	Keyless Entry Control Module																																																								
P	2015	Cruze	Body	Right Side Object Detection Control Module																																																								
P	2015	Cruze	Body	Left Side Object Detection Control Module																																																								
P	2015	Cruze	Body	Parking Assist Control Module																																																								
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	1.4L LUJ Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	1.6L L2W Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	1.6L L2W Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Automatic Transmission																																																								
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Edge Manual Transmission																																																								
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
P	2016	Cruze	Powertrain	(C) 1.6L LDE Engine Face Manual Transmission																																																								
P	2016	Cruze	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	1.6L LVL Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	(F) 1.6L LXT Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	1.8L LFH Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	1.8L LFH Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	(G) 1.8L LWE Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	(G) 1.8L LWE Transmission Control Module																																																								
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2016	Cruze	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2016	Cruze	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2016	Cruze	Powertrain	Fuel Injector Control Module																																																								
P	2016	Cruze	Powertrain	Chassis Control Module																																																								
P	2016	Cruze	Chassis	Electronic Brake Control Module																																																								
P	2016	Cruze	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2016	Cruze	Chassis	Power Steering Control Module																																																								
P	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2016	Cruze	Body	Body Control Module Hatchback																																																								
P	2016	Cruze	Body	Body Control Module Sedan																																																								
P	2016	Cruze	Body	Body Control Module Station Wagon																																																								
P	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2016	Cruze	Body	Passenger Presence Module																																																								
P	2016	Cruze	Body	Instrument Cluster																																																								
P	2016	Cruze	Body	Trailer Interface Control Module																																																								
P	2016	Cruze	Body	Radio Other																																																								
P	2016	Cruze	Body	Radio (UF7)																																																								
P	2016	Cruze	Body	Multimedia Player Interface Module																																																								
P	2016	Cruze	Body	Mobile Telephone Control Module																																																								
P	2016	Cruze	Body	Telematics Communication Interface Control Module																																																								
P	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
P	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																								
P	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																								
P	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																								
P	2016	Cruze	Body	Front Seat Heating Control Module																																																								
P	2016	Cruze	Body	Keyless Entry Control Module																																																								
P	2016	Cruze	Body	Right Side Object Detection Control Module																																																								
P	2016	Cruze	Body	Left Side Object Detection Control Module																																																								
P	2016	Cruze	Body	Parking Assist Control Module																																																								
P	2016	Cruze	Body	Steering Column Lock Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2011	Volt	Powertrain	Engine Control Module																																																								
R	2011	Volt	Powertrain	Trasmission Control Module																																																								
R	2011	Volt	Powertrain	Fuel Pump Control Module																																																								
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module																																																								
R	2011	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																								
R	2011	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2011	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2011	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																								
R	2011	Volt	Chassis	Electronic Brake Control Module																																																								
R	2011	Volt	Chassis	Parking Brake Control Module																																																								
R	2011	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																								
R	2011	Volt	Chassis	Power Steering Control Module																																																								
R	2011	Volt	Chassis	Steering Wheel Angle Sensor Module																																																								
R	2011	Volt	Body	Body Control Module																																																								
R	2011	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2011	Volt	Body	Passenger Presence Module																																																								
R	2011	Volt	Body	Instrument Cluster																																																								
R	2011	Volt	Body	Radio																																																								
R	2011	Volt	Body	Digital Radio Receiver Control Module																																																								
R	2011	Volt	Body	Mobile Telephone Control Module																																																								
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2011	Volt	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2011	Volt	Body	Remote Heater and Air Conditioning Control Module																																																								
R	2011	Volt	Body	Electric A/C Compressor Control Module																																																								
R	2011	Volt	Body	Coolant Heater Control Module																																																								
R	2011	Volt	Body	Keyless Entry Control Module																																																								
R	2011	Volt	Body	Parking Assist Control Module																																																								
R	2011	Volt	Body	Steering Column Lock Control Module																																																								
R	2011	Volt	Body	Battery Charger Control Module																																																								
R	2011	Volt	Body	Battery Energy Control Module																																																								
R	2012	Volt	Powertrain	Engine Control Module																																																								
R	2012	Volt	Powertrain	Trasmission Control Module																																																								
R	2012	Volt	Powertrain	Fuel Pump Control Module																																																								
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module																																																								
R	2012	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																								
R	2012	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2012	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2012	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																								
R	2012	Volt	Chassis	Electronic Brake Control Module																																																								
R	2012	Volt	Chassis	Parking Brake Control Module																																																								
R	2012	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																								
R	2012	Volt	Chassis	Power Steering Control Module																																																								
R	2012	Volt	Chassis	Steering Wheel Angle Sensor Module																																																								
R	2012	Volt	Body	Body Control Module																																																								
R	2012	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2012	Volt	Body	Passenger Presence Module																																																								
R	2012	Volt	Body	Instrument Cluster																																																								
R	2012	Volt	Body	Radio																																																								
R	2012	Volt	Body	Digital Radio Receiver Control Module																																																								
R	2012	Volt	Body	Mobile Telephone Control Module																																																								
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 9																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2012	Volt	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2012	Volt	Body	Remote Heater and Air Conditioning Control Module																																																								
R	2012	Volt	Body	Electric A/C Compressor Control Module																																																								
R	2012	Volt	Body	Coolant Heater Control Module																																																								
R	2012	Volt	Body	Keyless Entry Control Module																																																								
R	2012	Volt	Body	Parking Assist Control Module																																																								
R	2012	Volt	Body	Steering Column Lock Control Module																																																								
R	2012	Volt	Body	Battery Charger Control Module																																																								
R	2012	Volt	Body	Battery Energy Control Module																																																								
R	2013	Volt	Powertrain	Engine Control Module																																																								
R	2013	Volt	Powertrain	Trasmission Control Module																																																								
R	2013	Volt	Powertrain	Fuel Pump Control Module																																																								
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module																																																								
R	2013	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																								
R	2013	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2013	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2013	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																								
R	2013	Volt	Chassis	Electronic Brake Control Module																																																								
R	2013	Volt	Chassis	Parking Brake Control Module																																																								
R	2013	Volt	Chassis	Multi-Axis Acceleration Sensor Module																																																								
R	2013	Volt	Chassis	Power Steering Control Module																																																								
R	2013	Volt	Chassis	Steering Wheel Angle Sensor Module																																																								
R	2013	Volt	Body	Body Control Module																																																								
R	2013	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2013	Volt	Body	Passenger Presence Module																																																								
R	2013	Volt	Body	Instrument Cluster																																																								
R	2013	Volt	Body	Radio																																																								
R	2013	Volt	Body	Digital Radio Receiver Control Module																																																								
R	2013	Volt	Body	Multimedia Player Interface Module																																																								
R	2013	Volt	Body	Mobile Telephone Control Module																																																								
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2013	Volt	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2013	Volt	Body	HVAC Control Module																																																								
R	2013	Volt	Body	Electric A/C Compressor Control Module																																																								
R	2013	Volt	Body	Coolant Heater Control Module																																																								
R	2013	Volt	Body	Front Seat Heating Control Module																																																								
R	2013	Volt	Body	Keyless Entry Control Module																																																								
R	2013	Volt	Body	Parking Assist Control Module																																																								
R	2013	Volt	Body	Frontview Camera Module																																																								
R	2013	Volt	Body	Steering Column Lock Control Module																																																								
R	2013	Volt	Body	Battery Charger Control Module																																																								
R	2013	Volt	Body	Battery Energy Control Module																																																								
R	2014	Volt	Powertrain	Engine Control Module																																																								
R	2014	Volt	Powertrain	Trasmission Control Module																																																								
R	2014	Volt	Powertrain	Chassis Control Module																																																								
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module																																																								
R	2014	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																								
R	2014	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2014	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2014	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																								
R	2014	Volt	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2014	Volt	Chassis	Parking Brake Control Module																																																								
R	2014	Volt	Chassis	Power Steering Control Module																																																								
R	2014	Volt	Chassis	Steering Wheel Angle Sensor Module																																																								
R	2014	Volt	Body	Body Control Module																																																								
R	2014	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2014	Volt	Body	Passenger Presence Module																																																								
R	2014	Volt	Body	Instrument Cluster																																																								
R	2014	Volt	Body	Radio																																																								
R	2014	Volt	Body	Digital Radio Receiver Control Module																																																								
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2014	Volt	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2014	Volt	Body	HVAC Control Module																																																								
R	2014	Volt	Body	Electric A/C Compressor Control Module																																																								
R	2014	Volt	Body	Coolant Heater Control Module																																																								
R	2014	Volt	Body	Front Seat Heating Control Module																																																								
R	2014	Volt	Body	Keyless Entry Control Module																																																								
R	2014	Volt	Body	Parking Assist Control Module																																																								
R	2014	Volt	Body	Frontview Camera Module																																																								
R	2014	Volt	Body	Steering Column Lock Control Module																																																								
R	2014	Volt	Body	Battery Charger Control Module																																																								
R	2014	Volt	Body	Battery Energy Control Module																																																								
R	2015	Volt	Powertrain	Engine Control Module																																																								
R	2015	Volt	Powertrain	Trasmission Control Module																																																								
R	2015	Volt	Powertrain	Chassis Control Module																																																								
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module																																																								
R	2015	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																								
R	2015	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2015	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2015	Volt	Powertrain	Auxiliary Transmission Fluid Pump																																																								
R	2015	Volt	Chassis	Electronic Brake Control Module																																																								
R	2015	Volt	Chassis	Parking Brake Control Module																																																								
R	2015	Volt	Chassis	Power Steering Control Module																																																								
R	2015	Volt	Chassis	Steering Wheel Angle Sensor Module																																																								
R	2015	Volt	Body	Body Control Module																																																								
R	2015	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2015	Volt	Body	Passenger Presence Module																																																								
R	2015	Volt	Body	Instrument Cluster																																																								
R	2015	Volt	Body	Radio																																																								
R	2015	Volt	Body	Digital Radio Receiver Control Module																																																								
R	2015	Volt	Body	Telematics Communication Interface Control Module																																																								
R	2015	Volt	Body	HVAC Control Module																																																								
R	2015	Volt	Body	Electric A/C Compressor Control Module																																																								
R	2015	Volt	Body	Coolant Heater Control Module																																																								
R	2015	Volt	Body	Front Seat Heating Control Module																																																								
R	2015	Volt	Body	Keyless Entry Control Module																																																								
R	2015	Volt	Body	Parking Assist Control Module																																																								
R	2015	Volt	Body	Frontview Camera Module																																																								
R	2015	Volt	Body	Steering Column Lock Control Module																																																								
R	2015	Volt	Body	Battery Charger Control Module																																																								
R	2015	Volt	Body	Battery Energy Control Module																																																								
R	2016	Volt	Powertrain	Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module																																																								
R	2016	Volt	Powertrain	Hybrid Powertrain Control Module 2																																																								
R	2016	Volt	Powertrain	Drive Motor Control Module 1																																																								
R	2016	Volt	Powertrain	Drive Motor Control Module 2																																																								
R	2016	Volt	Chassis	Electronic Brake Control Module																																																								
R	2016	Volt	Chassis	Brake Booster Control Module																																																								
R	2016	Volt	Chassis	Power Steering Control Module																																																								
R	2016	Volt	Body	Body Control Module																																																								
R	2016	Volt	Body	Pedestrian Alert Sound Control Module																																																								
R	2016	Volt	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2016	Volt	Body	Passenger Presence Module																																																								
R	2016	Volt	Body	Instrument Cluster																																																								
R	2016	Volt	Body	Radio Controls																																																								
R	2016	Volt	Body	HVAC Controls																																																								
R	2016	Volt	Body	Radio																																																								
R	2016	Volt	Body	Amplifier																																																								
R	2016	Volt	Body	Human Machine Interface Control Module																																																								
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 9.7																																																								
R	2016	Volt	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2016	Volt	Body	HVAC Control Module																																																								
R	2016	Volt	Body	Electric A/C Compressor Control Module																																																								
R	2016	Volt	Body	Keyless Entry Control Module																																																								
R	2016	Volt	Body	Right Side Object Detection Control Module																																																								
R	2016	Volt	Body	Left Side Object Detection Control Module																																																								
R	2016	Volt	Body	Parking Assist Control Module																																																								
R	2016	Volt	Body	Frontview Camera Module																																																								
R	2016	Volt	Body	Steering Column Lock Control Module																																																								
R	2016	Volt	Body	Battery Energy Control Module																																																								
R	2016	Volt	Body	Long Range Radar Sensor Module																																																								
S	2004	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2004	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								
S	2004	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
S	2004	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																								
S	2004	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
S	2004	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
S	2004	Aveo	Powertrain	Transmission Control Module																																																								
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2004	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2004	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2004	Aveo	Body	Remote Function Actuation																																																								
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2005	Monza	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2005	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2005	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								
S	2005	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
S	2005	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																								
S	2005	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
S	2005	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
S	2005	Aveo	Powertrain	Transmission Control Module																																																								
S	2005	Aveo	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2005	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2005	Aveo	Body	Remote Function Actuation																																																								
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2006	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2006	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
S	2006	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																								
S	2006	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																								
S	2006	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
S	2006	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
S	2006	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2006	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2006	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2006	Aveo	Body	Remote Function Actuation																																																								
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2007	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2007	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
S	2007	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																								
S	2007	Aveo	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																								
S	2007	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
S	2007	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
S	2007	Aveo	Powertrain	Transmission Control Module 4 Speed																																																								
S	2007	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2007	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2007	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2007	Aveo	Body	Remote Function Actuation																																																								
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2008	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2008	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																								
S	2008	Aveo	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
S	2008	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																								
S	2008	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																								
S	2008	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
S	2008	Aveo	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
S	2008	Aveo	Powertrain	Transmission Control Module																																																								
S	2008	Aveo	Powertrain	Transmission Control Module																																																								
S	2008	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2008	Aveo	Chassis	Tire Pressure Monitor																																																								
S	2008	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2008	Aveo	Body	Remote Function Actuation																																																								
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2009	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2009	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																								
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
S	2009	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																								
S	2009	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																								
S	2009	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2009	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																								
S	2009	Aveo	Powertrain	Transmission Control Module																																																								
S	2009	Aveo	Powertrain	Transmission Control Module																																																								
S	2009	Aveo	Powertrain	Other Auto Transmission System																																																								
S	2009	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2009	Aveo	Chassis	Tire Pressure Monitor																																																								
S	2009	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2009	Aveo	Body	Remote Function Actuation																																																								
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2010	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2010	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																								
S	2010	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
S	2010	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																								
S	2010	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
S	2010	Aveo	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																								
S	2010	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																								
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2010	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2010	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2010	Aveo	Chassis	Tire Pressure Monitor																																																								
S	2010	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2010	Aveo	Body	Remote Function Actuation																																																								
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
S	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
S	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																								
S	2010	Sail	Powertrain	Transmission Control Module																																																								
S	2010	Sail	Chassis	Electronic Brake Control Module																																																								
S	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								
S	2011	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2011	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																								
S	2011	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
S	2011	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																								
S	2011	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
S	2011	Aveo	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																								
S	2011	Aveo	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																								
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2011	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2011	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2011	Aveo	Chassis	Tire Pressure Monitor																																																								
S	2011	Aveo	Body	Supplemental Inflatable Restraint																																																								
S	2011	Aveo	Body	Remote Function Actuation																																																								
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																								
S	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																								
S	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																								
S	2011	Sail	Powertrain	Transmission Control Module																																																								
S	2011	Sail	Chassis	Electronic Brake Control Module																																																								
S	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																								
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
S	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																								
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
S	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
S	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																								
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
S	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
S	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																								
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
S	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
S	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																								
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
S	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
S	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
S	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
S	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																								
S	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
S	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
S	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
S	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																								
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																								
S	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																								
S	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																								
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
S	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
S	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
S	2012	Aveo	Powertrain	Fuel Pump Control Module																																																								
S	2012	Aveo	Powertrain	Fuel Injector Control Module																																																								
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2012	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2012	Aveo	Chassis	Electric Power Steering Control Module																																																								
S	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2012	Aveo	Chassis	Tire Pressure Monitor																																																								
S	2012	Aveo	Body	Body Control Module Hatchback																																																								
S	2012	Aveo	Body	Body Control Module Sedan																																																								
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2012	Aveo	Body	Passenger Presence Module																																																								
S	2012	Aveo	Body	Instrument Cluster																																																								
S	2012	Aveo	Body	Radio																																																								
S	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																								
S	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
S	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
S	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								
S	2012	Aveo	Body	Front Seat Heating Control Module																																																								
S	2012	Aveo	Body	Remote Function Actuation																																																								
S	2012	Aveo	Body	Parking Assist Control Module																																																								
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2012	Chevy	Powertrain	(X)1.6L L4 LLQ Transmission Control Module																																																								
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																									
S	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																									
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																									
S	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																									
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
S	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																									
S	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																									
S	2012	Sail	Powertrain	Transmission Control Module																																																									
S	2012	Sail	Chassis	Electronic Brake Control Module																																																									
S	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																									
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
S	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
S	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
S	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
S	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
S	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
S	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
S	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																									
S	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
S	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
S	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
S	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
S	2013	Aveo	Powertrain	Fuel Injector Control Module																																																									
S	2013	Aveo	Powertrain	Fuel Pump Control Module																																																									
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
S	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2013	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2013	Aveo	Chassis	Electric Power Steering Control Module																																																									
S	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2013	Aveo	Body	Body Control Module Hatchback																																																									
S	2013	Aveo	Body	Body Control Module Sedan																																																									
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2013	Aveo	Body	Passenger Presence Module																																																									
S	2013	Aveo	Body	Instrument Cluster																																																									
S	2013	Aveo	Body	Radio																																																									
S	2013	Aveo	Body	Telematics Communication Interface Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
S	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
S	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								
S	2013	Aveo	Body	Front Seat Heating Control Module																																																								
S	2013	Aveo	Body	Remote Function Actuation																																																								
S	2013	Aveo	Body	Parking Assist Control Module																																																								
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
S	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
S	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
S	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
S	2013	Sail	Powertrain	Transmission Control Module																																																								
S	2013	Sail	Chassis	Electronic Brake Control Module																																																								
S	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																								
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
S	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
S	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								
S	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
S	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
S	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																								
S	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																								
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																								
S	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																								
S	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																								
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
S	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
S	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																								
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
S	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
S	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
S	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
S	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																								
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
S	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
S	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
S	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																								
S	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																								
S	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																								
S	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
S	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
S	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																								
S	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																								
S	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
S	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
S	2014	Aveo	Powertrain	Chassis Control Module																																																									
S	2014	Aveo	Powertrain	Fuel Injector Control Module																																																									
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2014	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2014	Aveo	Chassis	Power Steering Control Module																																																									
S	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2014	Aveo	Body	Body Control Module Hatchback																																																									
S	2014	Aveo	Body	Body Control Module Sedan																																																									
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	Aveo	Body	Instrument Cluster																																																									
S	2014	Aveo	Body	Radio																																																									
S	2014	Aveo	Body	Telematics Communication Interface Control Module																																																									
S	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
S	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
S	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
S	2014	Aveo	Body	Front Seat Heating Control Module																																																									
S	2014	Aveo	Body	Keyless Entry Control Module																																																									
S	2014	Aveo	Body	Parking Assist Control Module																																																									
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																									
S	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																									
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																									
S	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																									
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																									
S	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																									
S	2014	Sail	Powertrain	Transmission Control Module																																																									
S	2014	Sail	Chassis	Electronic Brake Control Module																																																									
S	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																									
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
S	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																									
S	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																									
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																									
S	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																									
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																									
S	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																									
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
S	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
S	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																								
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
S	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
S	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																								
S	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																								
S	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																								
S	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
S	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																								
S	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																								
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
S	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
S	2015	Aveo	Powertrain	Chassis Control Module																																																								
S	2015	Aveo	Powertrain	Fuel Injector Control Module																																																								
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2015	Aveo	Chassis	Electronic Brake Control Module																																																								
S	2015	Aveo	Chassis	Power Steering Control Module																																																								
S	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2015	Aveo	Body	Body Control Module Hatchback																																																								
S	2015	Aveo	Body	Body Control Module Sedan																																																								
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2015	Aveo	Body	Instrument Cluster																																																								
S	2015	Aveo	Body	Radio																																																								
S	2015	Aveo	Body	Telematics Communication Interface Control Module																																																								
S	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
S	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
S	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								
S	2015	Aveo	Body	Front Seat Heating Control Module																																																								
S	2015	Aveo	Body	Keyless Entry Control Module																																																								
S	2015	Aveo	Body	Parking Assist Control Module																																																								
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
S	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
S	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
S	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
S	2015	Sail	Powertrain	Transmission Control Module																																																								
S	2015	Sail	Chassis	Electronic Brake Control Module																																																								
S	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
S	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
S	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
S	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
S	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																									
S	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																									
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
S	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
S	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
S	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
S	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																									
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
S	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
S	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
S	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																									
S	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
S	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
S	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																									
S	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																									
S	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																									
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																									
S	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																									
S	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																									
S	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																									
S	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
S	2016	Aveo	Powertrain	Chassis Control Module																																																									
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2016	Aveo	Chassis	Electronic Brake Control Module																																																									
S	2016	Aveo	Chassis	Power Steering Control Module																																																									
S	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2016	Aveo	Body	Body Control Module Hatchback																																																									
S	2016	Aveo	Body	Body Control Module Sedan																																																									
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2016	Aveo	Body	Instrument Cluster																																																									
S	2016	Aveo	Body	Radio																																																									
S	2016	Aveo	Body	Telematics Communication Interface Control Module																																																									
S	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
S	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
S	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
S	2016	Aveo	Body	Front Seat Heating Control Module																																																									
S	2016	Aveo	Body	Parking Assist Control Module																																																									
S	2016	Aveo	Body	Keyless Entry Control Module																																																									
S	2016	Aveo	Body	Frontview Camera Module																																																									
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																									
S	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																								
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
S	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
S	2016	Sail	Powertrain	Transmission Control Module																																																								
S	2016	Sail	Chassis	Electronic Brake Control Module																																																								
S	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2004	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								
T	2004	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
T	2004	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																								
T	2004	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
T	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
T	2004	ALL	Powertrain	Transmission Control Module																																																								
T	2004	ALL	Chassis	Electronic Brake Control Module																																																								
T	2004	ALL	Chassis	Electronic Brake Control Module																																																								
T	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2004	ALL	Body	Remote Function Actuation																																																								
T	2005	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								
T	2005	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
T	2005	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																								
T	2005	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
T	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
T	2005	ALL	Powertrain	Transmission Control Module																																																								
T	2005	ALL	Chassis	Electronic Brake Control Module																																																								
T	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2005	ALL	Body	Remote Function Actuation																																																								
T	2006	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
T	2006	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																								
T	2006	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																								
T	2006	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
T	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
T	2006	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
T	2006	ALL	Chassis	Electronic Brake Control Module																																																								
T	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2006	ALL	Body	Remote Function Actuation																																																								
T	2007	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
T	2007	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																								
T	2007	ALL	Powertrain	(A)1.4L L4 LBJ Engine Control Module																																																								
T	2007	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
T	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																								
T	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																								
T	2007	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
T	2007	ALL	Chassis	Electronic Brake Control Module																																																								
T	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2007	ALL	Body	Remote Function Actuation																																																								
T	2008	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																								
T	2008	ALL	Powertrain	(T)1.2L L4 LY4 Engine Control Module																																																								
T	2008	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2008	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																									
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
T	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module India																																																									
T	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																									
T	2008	ALL	Powertrain	Transmission Control Module																																																									
T	2008	ALL	Powertrain	Transmission Control Module																																																									
T	2008	ALL	Chassis	Electronic Brake Control Module																																																									
T	2008	ALL	Chassis	Tire Pressure Monitor																																																									
T	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2008	ALL	Body	Remote Function Actuation																																																									
T	2008	ALL	Body	Passenger Presence System																																																									
T	2009	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module India																																																									
T	2009	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																									
T	2009	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																									
T	2009	ALL	Powertrain	Transmission Control Module																																																									
T	2009	ALL	Powertrain	Transmission Control Module																																																									
T	2009	ALL	Chassis	Electronic Brake Control Module																																																									
T	2009	ALL	Chassis	Tire Pressure Monitor																																																									
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2009	ALL	Body	Instrument Panel Cluster																																																									
T	2009	ALL	Body	Passenger Presence System																																																									
T	2009	ALL	Body	Theft Deterrent Module																																																									
T	2009	ALL	Body	Radio																																																									
T	2009	ALL	Body	Remote Function Actuation																																																									
T	2010	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																									
T	2010	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																									
T	2010	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																									
T	2010	ALL	Powertrain	Transmission Control Module																																																									
T	2010	ALL	Powertrain	Transmission Control Module																																																									
T	2010	ALL	Chassis	Electronic Brake Control Module																																																									
T	2010	ALL	Chassis	Tire Pressure Monitor																																																									
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2010	ALL	Body	Instrument Panel Cluster																																																									
T	2010	ALL	Body	Passenger Presence System																																																									
T	2010	ALL	Body	Theft Deterrent Module																																																									
T	2010	ALL	Body	Radio																																																									
T	2010	ALL	Body	Remote Function Actuation																																																									
T	2011	ALL	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																									
T	2011	ALL	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																									
T	2011	ALL	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																									
T	2011	ALL	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																									
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																									
T	2011	ALL	Powertrain	(F)1.6L L4 LXT Engine Control Module Argentia																																																									
T	2011	ALL	Powertrain	(E)1.6L L4 LXV Engine Control Module																																																									
T	2011	ALL	Powertrain	(G)1.6L L4 LXV Engine Control Module																																																									
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2011	ALL	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																									
T	2011	ALL	Chassis	Electronic Brake Control Module																																																									
T	2011	ALL	Chassis	Tire Pressure Monitor																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2011	ALL	Body	Instrument Panel Cluster																																																								
T	2011	ALL	Body	Passenger Presence System																																																								
T	2011	ALL	Body	Theft Deterrent Module																																																								
T	2011	ALL	Body	Radio																																																								
T	2011	ALL	Body	Remote Function Actuation																																																								
T	2012	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																								
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.2L LDC Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.2L LWD Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.3L LDV Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.3L LSF Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
T	2012	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
T	2012	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																								
T	2012	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
T	2012	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.6L LDE Transmission Control Module																																																								
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																								
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Automatic Transmission																																																								
T	2012	Aveo	Powertrain	(H) 1.8L LUW Engine Control Module Manual Transmission																																																								
T	2012	Aveo	Powertrain	(H) 1.8L LUW Transmission Control Module																																																								
T	2012	Aveo	Powertrain	Fuel Injector Control Module																																																								
T	2012	Aveo	Powertrain	Fuel Pump Control Module																																																								
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
T	2012	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2012	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2012	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2012	Aveo	Chassis	Electric Power Steering Control Module																																																								
T	2012	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2012	Aveo	Chassis	Tire Pressure Monitor																																																								
T	2012	Aveo	Body	Body Control Module Hatchback																																																								
T	2012	Aveo	Body	Body Control Module Sedan																																																								
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	Aveo	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2012	Aveo	Body	Instrument Cluster																																																								
T	2012	Aveo	Body	Radio																																																								
T	2012	Aveo	Body	Telematic Vehicle Localization and Immobilization Control Module																																																								
T	2012	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
T	2012	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
T	2012	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								
T	2012	Aveo	Body	Front Seat Heating Control Module																																																								
T	2012	Aveo	Body	Remote Function Actuation																																																								
T	2012	Aveo	Body	Parking Assist Control Module																																																								
T	2013	Aveo	Powertrain	(D)1.2L L4 LMU Engine Control Module																																																								
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
T	2013	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
T	2013	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
T	2013	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
T	2013	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
T	2013	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
T	2013	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
T	2013	Aveo	Powertrain	(7)1.4L L4 L95 Engine Control Module																																																								
T	2013	Aveo	Powertrain	(W)1.4L L4 LDT Engine Control Module																																																								
T	2013	Aveo	Powertrain	(Y)1.5L L4 LV8 Engine Control Module																																																								
T	2013	Aveo	Powertrain	(F)1.6L L4 LXT Engine Control Module																																																								
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
T	2013	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
T	2013	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
T	2013	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
T	2013	Aveo	Powertrain	Fuel Injector Control Module																																																								
T	2013	Aveo	Powertrain	Fuel Pump Control Module																																																								
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
T	2013	Aveo	Powertrain	ML4/MLQ Transmission Control Module 4 Speed																																																								
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2013	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2013	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2013	Aveo	Chassis	Electric Power Steering Control Module																																																								
T	2013	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2013	Aveo	Body	Body Control Module Hatchback																																																								
T	2013	Aveo	Body	Body Control Module Sedan																																																								
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2013	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2013	Aveo	Body	Passenger Presence Module																																																								
T	2013	Aveo	Body	Instrument Cluster																																																								
T	2013	Aveo	Body	Radio																																																								
T	2013	Aveo	Body	Telematics Communication Interface Control Module																																																								
T	2013	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
T	2013	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
T	2013	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2013	Aveo	Body	Front Seat Heating Control Module																																																									
T	2013	Aveo	Body	Remote Function Actuation																																																									
T	2013	Aveo	Body	Parking Assist Control Module																																																									
T	2014	Aveo	Powertrain	1.2L LMU Engine Control Module																																																									
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L L95 Engine Control Module																																																									
T	2014	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																									
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																									
T	2014	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
T	2014	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																									
T	2014	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	1.6L LED Transmission Control Module																																																									
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																									
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																									
T	2014	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																									
T	2014	Aveo	Powertrain	Chassis Control Module																																																									
T	2014	Aveo	Powertrain	Fuel Injector Control Module																																																									
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2014	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2014	Aveo	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2014	Aveo	Chassis	Power Steering Control Module																																																									
T	2014	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2014	Aveo	Body	Body Control Module Hatchback																																																									
T	2014	Aveo	Body	Body Control Module Sedan																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2014	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2014	Aveo	Body	Instrument Cluster																																																								
T	2014	Aveo	Body	Radio																																																								
T	2014	Aveo	Body	Telematics Communication Interface Control Module																																																								
T	2014	Aveo	Body	HVAC Control Module Heater Only (C41)																																																								
T	2014	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
T	2014	Aveo	Body	HVAC Control Module Single Zone (C60)																																																								
T	2014	Aveo	Body	Front Seat Heating Control Module																																																								
T	2014	Aveo	Body	Keyless Entry Control Module																																																								
T	2014	Aveo	Body	Parking Assist Control Module																																																								
T	2015	Aveo	Powertrain	1.2L LMU Engine Control Module																																																								
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																								
T	2015	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																								
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																								
T	2015	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																								
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
T	2015	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																								
T	2015	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																								
T	2015	Aveo	Powertrain	1.4L L95 Engine Control Module																																																								
T	2015	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																								
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Automatic Transmission																																																								
T	2015	Aveo	Powertrain	1.4L LDT Engine Control Module Manual Transmission																																																								
T	2015	Aveo	Powertrain	1.4L LDT Transmission Control Module																																																								
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Automatic Transmission																																																								
T	2015	Aveo	Powertrain	1.4L L2N Engine Control Module Manual Transmission																																																								
T	2015	Aveo	Powertrain	1.4L L2N Transmission Control Module																																																								
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
T	2015	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
T	2015	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																								
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
T	2015	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
T	2015	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																								
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
T	2015	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
T	2015	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
T	2015	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																								
T	2015	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																								
T	2015	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																								
T	2015	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																								
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																								
T	2015	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																								
T	2015	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																								
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																								
T	2015	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																								
T	2015	Aveo	Powertrain	1.6L LED Transmission Control Module																																																								
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Automatic Transmission																																																								
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Engine Control Module Manual Transmission																																																								
T	2015	Aveo	Powertrain	(D) 1.6L LFJ Transmission Control Module																																																								
T	2015	Aveo	Powertrain	Chassis Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2015	Aveo	Powertrain	Fuel Injector Control Module																																																								
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2015	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2015	Aveo	Chassis	Power Steering Control Module																																																									
T	2015	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2015	Aveo	Body	Body Control Module Hatchback																																																									
T	2015	Aveo	Body	Body Control Module Sedan																																																									
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Aveo	Body	Instrument Cluster																																																									
T	2015	Aveo	Body	Radio																																																									
T	2015	Aveo	Body	Telematics Communication Interface Control Module																																																									
T	2015	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
T	2015	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
T	2015	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
T	2015	Aveo	Body	Front Seat Heating Control Module																																																									
T	2015	Aveo	Body	Keyless Entry Control Module																																																									
T	2015	Aveo	Body	Parking Assist Control Module																																																									
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.2L LDC Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.2L LWD Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.3L LSF Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.4L L95 Engine Control Module																																																									
T	2016	Aveo	Powertrain	1.4L L95 Transmission Control Module																																																									
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.4L LDD Transmission Control Module																																																									
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.4L LUJ Transmission Control Module																																																									
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
T	2016	Aveo	Powertrain	1.5L LV8 Engine Control Module																																																									
T	2016	Aveo	Powertrain	1.5L LV8 Transmission Control Module																																																									
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	(C) 1.6L LDE Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	(C) 1.6L LDE Transmission Control Module																																																									
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.6L LED Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.6L LED Transmission Control Module																																																									
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Automatic Transmission																																																									
T	2016	Aveo	Powertrain	1.6L LFJ Engine Control Module Manual Transmission																																																									
T	2016	Aveo	Powertrain	1.6L LFJ Transmission Control Module																																																									
T	2016	Aveo	Powertrain	(F) 1.6L LXT Engine Control Module																																																									
T	2016	Aveo	Powertrain	(F) 1.6L LXT Transmission Control Module																																																									
T	2016	Aveo	Powertrain	Chassis Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																								
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2016	Aveo	Chassis	Electronic Brake Control Module																																																									
T	2016	Aveo	Chassis	Power Steering Control Module																																																									
T	2016	Aveo	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2016	Aveo	Body	Body Control Module Hatchback																																																									
T	2016	Aveo	Body	Body Control Module Sedan																																																									
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2016	Aveo	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2016	Aveo	Body	Instrument Cluster																																																									
T	2016	Aveo	Body	Radio																																																									
T	2016	Aveo	Body	Telematics Communication Interface Control Module																																																									
T	2016	Aveo	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
T	2016	Aveo	Body	HVAC Control Module Heater Only (C41)																																																									
T	2016	Aveo	Body	HVAC Control Module Single Zone (C60)																																																									
T	2016	Aveo	Body	Front Seat Heating Control Module																																																									
T	2016	Aveo	Body	Parking Assist Control Module																																																									
T	2016	Aveo	Body	Keyless Entry Control Module																																																									
T	2016	Aveo	Body	Frontview Camera Module																																																									
U	2004	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
U	2004	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																									
U	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
U	2004	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																									
U	2004	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																									
U	2004	ALL	Chassis	Electronic Brake Control Module																																																									
U	2004	ALL	Chassis	Electronic Brake Control Module																																																									
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
U	2004	ALL	Body	Remote Function Actuation																																																									
U	2005	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
U	2005	ALL	Powertrain	(U)1.6L L4 L91 Engine Control Module																																																									
U	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
U	2005	ALL	Powertrain	ML4/MLQ 4 Speed Automatic																																																									
U	2005	ALL	Powertrain	MFA Transmission Control Module 4 Speed																																																									
U	2005	ALL	Chassis	Electronic Brake Control Module																																																									
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
U	2005	ALL	Body	Remote Function Actuation																																																									
U	2006	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
U	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
U	2006	ALL	Powertrain	Transmission Control Module																																																									
U	2006	ALL	Chassis	Electronic Brake Control Module																																																									
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
U	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
U	2006	ALL	Body	Remote Function Actuation																																																									
U	2007	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																									
U	2007	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																									
U	2007	ALL	Powertrain	Transmission Control Module																																																									
U	2007	ALL	Chassis	Electronic Brake Control Module																																																									
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
U	2007	ALL	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
U	2007	ALL	Body	Remote Function Actuation																																																								
U	2008	ALL	Powertrain	(6)1.6L L4 L91 Engine Control Module																																																								
U	2008	ALL	Powertrain	(6)1.6L L4 LXT Engine Control Module																																																								
U	2008	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
U	2008	ALL	Powertrain	Transmission Control Module																																																								
U	2008	ALL	Chassis	Electronic Brake Control Module																																																								
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2008	ALL	Body	Remote Function Actuation																																																								
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
U	2010	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
U	2010	Sail	Powertrain	1.4L LCU Engine Control Module																																																								
U	2010	Sail	Powertrain	Transmission Control Module																																																								
U	2010	Sail	Chassis	Electronic Brake Control Module																																																								
U	2010	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																								
U	2011	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																								
U	2011	Sail	Powertrain	1.4L LCU Engine Control Module																																																								
U	2011	Sail	Powertrain	Transmission Control Module																																																								
U	2011	Sail	Chassis	Electronic Brake Control Module																																																								
U	2011	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Automatic Transmission																																																								
U	2012	Sail	Powertrain	1.19L LC5 Engine Control Module Manual Transmission																																																								
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Automatic Transmission																																																								
U	2012	Sail	Powertrain	(D) 1.2L LMU Engine Control Module Manual Transmission																																																								
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
U	2012	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
U	2012	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
U	2012	Sail	Powertrain	Transmission Control Module																																																								
U	2012	Sail	Chassis	Electronic Brake Control Module																																																								
U	2012	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
U	2013	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
U	2013	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
U	2013	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
U	2013	Sail	Powertrain	Transmission Control Module																																																								
U	2013	Sail	Chassis	Electronic Brake Control Module																																																								
U	2013	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
U	2014	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Automatic Transmission																																																								
U	2014	Sail	Powertrain	(S) 1.3L LDV Engine Control Module Manual Transmission																																																								
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
U	2014	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
U	2014	Sail	Powertrain	Transmission Control Module																																																								
U	2014	Sail	Chassis	Electronic Brake Control Module																																																								
U	2014	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
U	2015	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Automatic Transmission																																																								
U	2015	Sail	Powertrain	1.3L LDV Engine Control Module Manual Transmission																																																								
U	2015	Sail	Powertrain	1.3L LEW Engine Control Module																																																								
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
U	2015	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
U	2015	Sail	Powertrain	1.5L L2B Engine Control Module																																																								
U	2015	Sail	Powertrain	Transmission Control Module																																																								
U	2015	Sail	Chassis	Electronic Brake Control Module																																																								
U	2015	Sail	Chassis	Electronic Brake Control Module																																																								
U	2015	Sail	Chassis	Power Steering Control Module																																																								
U	2015	Sail	Body	Body Control Module																																																								
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2015	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2015	Sail	Body	Radio/HVAC Control																																																								
U	2015	Sail	Body	HVAC Control Module																																																								
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Automatic Transmission																																																								
U	2016	Sail	Powertrain	1.2L LMU Engine Control Module Manual Transmission																																																								
U	2016	Sail	Powertrain	1.2L LMU Transmission Control Module																																																								
U	2016	Sail	Powertrain	1.3L LDV Engine Control Module																																																								
U	2016	Sail	Powertrain	1.3L LDV Transmission Control Module																																																								
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Automatic Transmission																																																								
U	2016	Sail	Powertrain	1.4L LCU Engine Control Module Manual Transmission																																																								
U	2016	Sail	Powertrain	1.4L LCU Transmission Control Module																																																								
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Automatic Transmission																																																								
U	2016	Sail	Powertrain	1.5L L2B Engine Control Module Manual Transmission																																																								
U	2016	Sail	Powertrain	1.5L L2B Transmission Control Module																																																								
U	2016	Sail	Chassis	Electronic Brake Control Module																																																								
U	2016	Sail	Chassis	Electronic Brake Control Module																																																								
U	2016	Sail	Chassis	Power Steering Control Module																																																								
U	2016	Sail	Body	Body Control Module																																																								
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2016	Sail	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
U	2016	Sail	Body	Radio/HVAC Control																																																								
U	2016	Sail	Body	Radio																																																								
U	2016	Sail	Body	HVAC Control Module																																																								
V	2004	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
V	2004	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
V	2004	ALL	Powertrain	Transmission Control Module 4 Speed																																																								
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																								
V	2004	ALL	Chassis	Anti-lock Brake System Traction Control No																																																								
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2004	ALL	Body	ISU																																																								
V	2005	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
V	2005	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								
V	2005	ALL	Powertrain	Transmission Control Module 4 Speed																																																								
V	2005	ALL	Chassis	Electronic Brake Control Module																																																								
V	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2005	ALL	Body	ISU																																																								
V	2006	ALL	Powertrain	(Z)2.0L L4 L34 Engine Control Module																																																								
V	2006	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
V	2006	ALL	Powertrain	Transmission Control Module 4 Speed																																																									
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control Yes																																																									
V	2006	ALL	Chassis	Anti-lock Brake System Traction Control No																																																									
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2006	ALL	Body	ISU																																																									
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Engine Control Module																																																									
V	2007	ALL	Powertrain	(P)2.0L L6 LBM Alternative Fuel Fuel Injector Control Module																																																									
V	2007	ALL	Powertrain	(B)1.8L L4 LDA Engine Control Module																																																									
V	2007	ALL	Powertrain	(R)2.0L L4 LLW Engine Control Module																																																									
V	2007	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
V	2007	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
V	2007	ALL	Powertrain	Transmission Control Module 4 Speed																																																									
V	2007	ALL	Powertrain	Transmission Control Module 5 Speed																																																									
V	2007	ALL	Chassis	Electronic Brake Control Module																																																									
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2007	ALL	Body	ISU																																																									
V	2008	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
V	2008	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
V	2008	ALL	Powertrain	Transmission Control Module 6 Speed																																																									
V	2008	ALL	Chassis	Electronic Brake Control Module																																																									
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2008	ALL	Body	ISU																																																									
V	2009	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
V	2009	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
V	2009	ALL	Powertrain	Transmission Control Module 6 Speed																																																									
V	2009	ALL	Chassis	Electronic Brake Control Module																																																									
V	2009	ALL	Body	ISU																																																									
V	2010	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																									
V	2010	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
V	2010	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
V	2010	ALL	Powertrain	Transmission Control Module 6 Speed																																																									
V	2010	ALL	Chassis	Electronic Brake Control Module																																																									
V	2010	ALL	Body	ISU																																																								
V	2011	ALL	Powertrain	(F)2.0L L4 LLW Engine Control Module																																																									
V	2011	ALL	Powertrain	(K)2.0L L6 LBM Engine Control Module																																																									
V	2011	ALL	Powertrain	(L)2.5L L6 LBK Engine Control Module																																																									
V	2011	ALL	Powertrain	Transmission Control Module 6 Speed																																																									
V	2011	ALL	Chassis	Electronic Brake Control Module																																																									
V	2011	ALL	Body	ISU																																																								
W	2004	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																									
W	2004	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																									
W	2004	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																									
W	2004	ALL	Powertrain	Transmission Control Module																																																									
W	2004	ALL	Body	Body Control Module																																																									
W	2004	ALL	Body	Digital Radio Receiver																																																									
W	2004	ALL	Body	Driver Information Center																																																								
W	2004	ALL	Body	Heating and Air Conditioning																																																									
W	2004	ALL	Body	Instrument Panel Cluster																																																									
W	2004	ALL	Body	Personalization																																																									
W	2004	ALL	Body	Radio	V	V	V																																																						

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
W	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
W	2005	ALL	Powertrain	(E)3.4L V6 LA1 Engine Control Module																																																									
W	2005	ALL	Powertrain	(K)3.8L V6 L36 Engine Control Module																																																									
W	2005	ALL	Powertrain	(1)3.8L V6 L67 Engine Control Module																																																									
W	2005	ALL	Powertrain	Transmission Control Module																																																									
W	2005	ALL	Body	Body Control Module																																																									
W	2005	ALL	Body	Digital Radio Receiver																																																									
W	2005	ALL	Body	Driver Information Center																																																									
W	2005	ALL	Body	Heating and Air Conditioning																																																									
W	2005	ALL	Body	Instrument Panel Cluster																																																									
W	2005	ALL	Body	Personalization																																																									
W	2005	ALL	Body	Radio	V	V	V																																																						
W	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
W	2006	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module				V																																																					
W	2006	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module				V																																																					
W	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module				V																																																					
W	2006	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module					V	V	V																																																		
W	2006	ALL	Powertrain	Transmission Control Module																																																									
W	2006	ALL	Chassis	Anti-lock Brake System																																																									
W	2006	ALL	Body	Digital Radio Receiver																																																									
W	2006	ALL	Body	Radio																																																									
W	2006	ALL	Body	Instrument Panel Cluster																																																									
W	2006	ALL	Body	Seat																																																									
W	2006	ALL	Body	Theft Deterrent Module																																																									
W	2006	ALL	Body	Body Control Module																																																									
W	2006	ALL	Body	HVAC C67 Single								V																																																	
W	2006	ALL	Body	HVAC CJ3 Dual								V																																																	
W	2006	ALL	Body	Remote Control Door Lock Receiver																																																									
W	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
W	2006	ALL	Body	Passenger Presence System																																																									
W	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																									
W	2007	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																									
W	2007	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module					V																																																				
W	2007	ALL	Powertrain	(R)3.9L V6 LZ8 Engine Control Module																																																									
W	2007	ALL	Powertrain	Transmission Control Module																																																									
W	2007	ALL	Chassis	Electronic Brake Control Module																																																									
W	2007	ALL	Body	Body Control Module																																																									
W	2007	ALL	Body	Digital Radio Receiver																																																									
W	2007	ALL	Body	Heated Seat Module																																																									
W	2007	ALL	Body	HVAC C67 Single									V																																																
W	2007	ALL	Body	HVAC CJ3 Dual								V	V																																																
W	2007	ALL	Body	Instrument Panel Cluster																																																									
W	2007	ALL	Body	Passenger Presence System																																																									
W	2007	ALL	Body	Radio																																																									
W	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
W	2007	ALL	Body	Theft Deterrent Module																																																									
W	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																																																									
W	2008	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																																																									
W	2008	ALL	Powertrain	(3)3.9L V6 LZG Engine Control Module																																																									
W	2008	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module										V	V																																														
W	2008	ALL	Powertrain	Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
W	2008	ALL	Chassis	Electronic Brake Control Module																																																										
W	2008	ALL	Body	Body Control Module																																																										
W	2008	ALL	Body	Digital Radio Receiver																																																										
W	2008	ALL	Body	Heated Seat Module																																																										
W	2008	ALL	Body	HVAC C67 Single									V																																																	
W	2008	ALL	Body	HVAC CJ3 Dual								V	V																																																		
W	2008	ALL	Body	Instrument Panel Cluster																																																											
W	2008	ALL	Body	Passenger Presence System																																																											
W	2008	ALL	Body	Radio																																																										
W	2008	ALL	Body	Remote Control Door Lock Receiver																																																											
W	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
W	2008	ALL	Body	Theft Deterrent Module																																																											
W	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module				V																																																							
W	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module				V																																																							
W	2009	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module				V																																																							
W	2009	ALL	Powertrain	(C)5.3L V8 LS4 Engine Control Module										V	V																																																
W	2009	ALL	Powertrain	Transmission Control Module																																																											
W	2009	ALL	Chassis	Electronic Brake Control Module																																																											
W	2009	ALL	Body	Body Control Module																																																											
W	2009	ALL	Body	Digital Radio Receiver																																																											
W	2009	ALL	Body	Heated Seat Module																																																											
W	2009	ALL	Body	HVAC C67 Single									V																																																	
W	2009	ALL	Body	HVAC CJ3 Dual								V	V																																																		
W	2009	ALL	Body	Instrument Panel Cluster																																																											
W	2009	ALL	Body	Passenger Presence System												V																																														
W	2009	ALL	Body	Radio																																																										
W	2009	ALL	Body	Remote Control Door Lock Receiver																																																											
W	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
W	2009	ALL	Body	Theft Deterrent Module																																																											
W	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module				V																																																							
W	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module				V																																																							
W	2010	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module				V																																																							
W	2010	ALL	Powertrain	Transmission Control Module																																																											
W	2010	ALL	Chassis	Electronic Brake Control Module																																																											
W	2010	ALL	Body	Body Control Module																																																											
W	2010	ALL	Body	Digital Radio Receiver																																																											
W	2010	ALL	Body	Heated Seat Module																																																											
W	2010	ALL	Body	HVAC C67 Single									V																																																	
W	2010	ALL	Body	HVAC CJ3 Dual								V	V																																																		
W	2010	ALL	Body	Instrument Panel Cluster																																																											
W	2010	ALL	Body	Passenger Presence System												V																																														
W	2010	ALL	Body	Radio																																																										
W	2010	ALL	Body	Remote Control Door Lock Receiver																																																											
W	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
W	2010	ALL	Body	Theft Deterrent Module																																																											
W	2011	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module				V																																																							
W	2011	ALL	Powertrain	(M)3.9L V6 LGD Engine Control Module				V																																																							
W	2011	ALL	Powertrain	Transmission Control Module																																																											
W	2011	ALL	Chassis	Electronic Brake Control Module																																																											
W	2011	ALL	Body	Body Control Module																																																											
W	2011	ALL	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
W	2011	ALL	Body	Heated Seat Module																																																										
W	2011	ALL	Body	HVAC C67 Single									V																																																	
W	2011	ALL	Body	HVAC CJ3 Dual								V	V																																																	
W	2011	ALL	Body	Instrument Panel Cluster																																																										
W	2011	ALL	Body	Passenger Presence System												V																																														
W	2011	ALL	Body	Radio																																																										
W	2011	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2011	ALL	Body	Theft Deterrent Module																																																										
W	2012	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
W	2012	ALL	Powertrain	Transmission Control Module																																																										
W	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
W	2012	ALL	Chassis	Electronic Brake Control Module																																																										
W	2012	ALL	Body	Body Control Module																																																										
W	2012	ALL	Body	Digital Radio Receiver																																																										
W	2012	ALL	Body	Heated Seat Module																																																										
W	2012	ALL	Body	HVAC C67 Single									V																																																	
W	2012	ALL	Body	HVAC CJ3 Dual								V	V																																																		
W	2012	ALL	Body	Instrument Panel Cluster																																																										
W	2012	ALL	Body	Passenger Presence System												V																																														
W	2012	ALL	Body	Radio																																																										
W	2012	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2012	ALL	Body	Theft Deterrent Module																																																										
W	2013	ALL	Powertrain	(3)3.6L V6 LFX Engine Control Module																																																										
W	2013	ALL	Powertrain	Transmission Control Module																																																										
W	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
W	2013	ALL	Chassis	Electronic Brake Control Module																																																										
W	2013	ALL	Body	Body Control Module																																																										
W	2013	ALL	Body	Digital Radio Receiver																																																										
W	2013	ALL	Body	Heated Seat Module																																																										
W	2013	ALL	Body	HVAC C67 Single									V																																																	
W	2013	ALL	Body	HVAC CJ3 Dual								V	V																																																		
W	2013	ALL	Body	Instrument Panel Cluster																																																										
W	2013	ALL	Body	Passenger Presence System												V																																														
W	2013	ALL	Body	Radio																																																										
W	2013	ALL	Body	Remote Control Door Lock Receiver																																																										
W	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
W	2013	ALL	Body	Theft Deterrent Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
W	2014	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																										
W	2014	Impala	Chassis	Electronic Brake Control Module																																																										
W	2014	Impala	Body	Body Control Module																																																										
W	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
W	2014	Impala	Body	Passenger Presence Module																																																										
W	2014	Impala	Body	Instrument Cluster																																																										
W	2014	Impala	Body	Radio																																																										
W	2014	Impala	Body	Digital Radio Receiver Control Module																																																										
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																										
W	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
W	2014	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
W	2014	Impala	Body	HVAC Manual Control Single Zone (C67)																																																								
W	2014	Impala	Body	Front Seat Heating Control Module																																																								
W	2014	Impala	Body	Remote Control Door Lock Receiver																																																								
W	2014	Impala	Body	Theft Deterrent Module																																																								
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Automatic Transmission																																																								
W	2014	Lumina	Powertrain	(2) 6.0L L77 Engine Control Module Manual Transmission																																																								
W	2014	Lumina	Powertrain	(2) 6.0L L77 Transmission Control Module																																																								
W	2014	Lumina	Powertrain	Fuel Injector Control Module																																																								
W	2014	Lumina	Powertrain	Chassis Control Module																																																								
W	2014	Lumina	Chassis	Electronic Brake Control Module																																																								
W	2014	Lumina	Chassis	Parking Brake Control Module																																																								
W	2014	Lumina	Chassis	Power Steering Control Module																																																								
W	2014	Lumina	Chassis	Steering Wheel Angle Sensor Module																																																								
W	2014	Lumina	Chassis	Suspension Control Module																																																								
W	2014	Lumina	Body	Body Control Module Coupe																																																								
W	2014	Lumina	Body	Body Control Module Sedan																																																								
W	2014	Lumina	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
W	2014	Lumina	Body	Instrument Cluster																																																								
W	2014	Lumina	Body	Head-Up Display Module																																																								
W	2014	Lumina	Body	Radio Control																																																								
W	2014	Lumina	Body	HVAC Control																																																								
W	2014	Lumina	Body	Headlamp Control Module																																																								
W	2014	Lumina	Body	Trailer Interface Control Module																																																								
W	2014	Lumina	Body	Radio																																																								
W	2014	Lumina	Body	HVAC Control Module																																																								
W	2014	Lumina	Body	Keyless Entry Control Module																																																								
W	2014	Lumina	Body	Right Side Object Detection Control Module																																																								
W	2014	Lumina	Body	Left Side Object Detection Control Module																																																								
W	2014	Lumina	Body	Parking Assist Control Module																																																								
W	2014	Lumina	Body	Frontview Camera Module																																																								
W	2014	Lumina	Body	Steering Column Lock Control Module																																																								
W	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
W	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
W	2015	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																								
W	2015	Impala	Chassis	Electronic Brake Control Module																																																								
W	2015	Impala	Body	Body Control Module																																																								
W	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
W	2015	Impala	Body	Passenger Presence Module																																																								
W	2015	Impala	Body	Instrument Cluster																																																								
W	2015	Impala	Body	Radio																																																								
W	2015	Impala	Body	Digital Radio Receiver Control Module																																																								
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 9																																																								
W	2015	Impala	Body	Telematics Communication Interface Control Module Version 10																																																								
W	2015	Impala	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
W	2015	Impala	Body	HVAC Manual Control Single Zone (C67)																																																								
W	2015	Impala	Body	Front Seat Heating Control Module																																																								
W	2015	Impala	Body	Remote Control Door Lock Receiver																																																								
W	2015	Impala	Body	Theft Deterrent Module																																																								
W	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
W	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
W	2016	Impala	Powertrain	(3) 3.6L LFX Chassis Control Module																																																								
W	2016	Impala	Chassis	Electronic Brake Control Module																																																								
W	2016	Impala	Body	Body Control Module																																																								
W	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
W	2016	Impala	Body	Passenger Presence Module																																																								
W	2016	Impala	Body	Instrument Cluster																																																								
W	2016	Impala	Body	Radio																																																								
W	2016	Impala	Body	Digital Radio Receiver Control Module																																																								
W	2016	Impala	Body	Telematics Communication Interface Control Module																																																								
W	2016	Impala	Body	HVAC Manual Control Dual Zone (CJ2)																																																								
W	2016	Impala	Body	HVAC Manual Control Single Zone (C67)																																																								
W	2016	Impala	Body	Front Seat Heating Control Module																																																								
W	2016	Impala	Body	Remote Control Door Lock Receiver																																																								
W	2016	Impala	Body	Theft Deterrent Module																																																								
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Auto																																																								
Y	2004	ALL	Powertrain	(G)5.7L V8 LS1 Engine Control Module Manual																																																								
Y	2004	ALL	Powertrain	(S)5.7L V8 LS6 Engine Control Module																																																								
Y	2004	ALL	Powertrain	Transmission Control Module													V																																											
Y	2004	ALL	Chassis	RTD																																																								
Y	2004	ALL	Body	Body Control Module														V	V																																									
Y	2004	ALL	Body	Heating and Air Conditioning																																																								
Y	2004	ALL	Body	Instrument Panel Cluster																V	V																																							
Y	2004	ALL	Body	Left Door Control Module																																																								
Y	2004	ALL	Body	Radio																																																								
Y	2004	ALL	Body	Remote Function Actuation																		V	V																																					
Y	2004	ALL	Body	Right Door Control Module																																																								
Y	2004	ALL	Body	Seat Control Module																V	V																																							
Y	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2005	ALL	Powertrain	Engine Control Module						V	V																																																	
Y	2005	ALL	Powertrain	Transmission Control Module																				V	V	V																																		
Y	2005	ALL	Chassis	Electronic Brake Control Module																																																								
Y	2005	ALL	Chassis	Electronic Suspension Control																																																								
Y	2005	ALL	Chassis	Steering Wheel and Column																																																								
Y	2005	ALL	Body	Amplifier																																																								
Y	2005	ALL	Body	Body Control Module																																																								
Y	2005	ALL	Body	Digital Radio Receiver																																																								
Y	2005	ALL	Body	Driver Door Module																																																								
Y	2005	ALL	Body	Driver Door Switch																																																								
Y	2005	ALL	Body	Driver Position Module																																																								
Y	2005	ALL	Body	Folding Top Module																							V																																	
Y	2005	ALL	Body	Head Up Display																																																								
Y	2005	ALL	Body	HVAC Control Module																																																								
Y	2005	ALL	Body	Instrument Panel Cluster																V	V							V																																
Y	2005	ALL	Body	Navigation Radio		V																																																						
Y	2005	ALL	Body	Passenger Door Module																																																								
Y	2005	ALL	Body	Radio		V																																																						
Y	2005	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2006	ALL	Powertrain	Engine Control Module						V	V																																																	
Y	2006	ALL	Powertrain	Exhaust Flow Control Module																																																								
Y	2006	ALL	Powertrain	Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
Y	2006	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2006	ALL	Chassis	Electronic Suspension Control																																																										
Y	2006	ALL	Chassis	Steering Wheel and Column																																																										
Y	2006	ALL	Body	Body Control Module																																																									
Y	2006	ALL	Body	CD Changer																																																									
Y	2006	ALL	Body	Digital Radio Receiver																																																									
Y	2006	ALL	Body	Driver Door Module																																																									
Y	2006	ALL	Body	Driver Door Switch																																																									
Y	2006	ALL	Body	Driver Position Module																																																									
Y	2006	ALL	Body	Folding Top Module																							V																																			
Y	2006	ALL	Body	Head Up Display																																																									
Y	2006	ALL	Body	HVAC Control Module																									V																																	
Y	2006	ALL	Body	Instrument Panel Cluster																V	V							V																																	
Y	2006	ALL	Body	Navigation Radio		V																																																							
Y	2006	ALL	Body	Passenger Door Module																																																									
Y	2006	ALL	Body	Radio		V																																																						
Y	2006	ALL	Body	Remote Control Door Lock Receiver																																																									
Y	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2007	ALL	Powertrain	Engine Control Module						V	V																																																		
Y	2007	ALL	Powertrain	Exhaust Flow Control Module																																																										
Y	2007	ALL	Powertrain	Transmission Control Module																																																										
Y	2007	ALL	Chassis	Electronic Brake Control Module																																																										
Y	2007	ALL	Chassis	Electronic Suspension Control																																																										
Y	2007	ALL	Body	Body Control Module																																																									
Y	2007	ALL	Body	CD Changer																																																									
Y	2007	ALL	Body	Digital Radio Receiver																																																									
Y	2007	ALL	Body	Driver Door Module																																																									
Y	2007	ALL	Body	Driver Door Switch																																																									
Y	2007	ALL	Body	Driver Position Module																																																									
Y	2007	ALL	Body	Folding Top Module																																																									
Y	2007	ALL	Body	Head Up Display																																																									
Y	2007	ALL	Body	HVAC Control Module																									V																																	
Y	2007	ALL	Body	Instrument Panel Cluster																V	V							V																																	
Y	2007	ALL	Body	Navigation Radio																																																									
Y	2007	ALL	Body	Passenger Door Module																																																									
Y	2007	ALL	Body	Radio																																																									
Y	2007	ALL	Body	Remote Control Door Lock Receiver																																																									
Y	2007	ALL	Body	Steering Column Lock Module																																																									
Y	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
Y	2008	ALL	Powertrain	Engine Control Module																																																									
Y	2008	ALL	Powertrain	Exhaust Flow Control Module																																																									
Y	2008	ALL	Powertrain	Transmission Control Module																																																									
Y	2008	ALL	Chassis	Electronic Brake Control Module																																																									
Y	2008	ALL	Chassis	Electronic Suspension Control																																																									
Y	2008	ALL	Body	Body Control Module																																																									
Y	2008	ALL	Body	CD Changer																																																									
Y	2008	ALL	Body	Digital Radio Receiver																																																									
Y	2008	ALL	Body	Driver Door Module																																																									
Y	2008	ALL	Body	Driver Door Switch																																																									
Y	2008	ALL	Body	Driver Position Module																																																									
Y	2008	ALL	Body	Folding Top Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
Y	2008	ALL	Body	Head Up Display																																																									
Y	2008	ALL	Body	HVAC Control Module																								V																																	
Y	2008	ALL	Body	Instrument Panel Cluster																V	V						V																																		
Y	2008	ALL	Body	Navigation Radio																																																								
Y	2008	ALL	Body	Passenger Door Module																																																								
Y	2008	ALL	Body	Radio																																																								
Y	2008	ALL	Body	Personal Audio Link Module																									V																															
Y	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2008	ALL	Body	Steering Column Lock Module																																																								
Y	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																								
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																								
Y	2009	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																								
Y	2009	ALL	Chassis	Electronic Brake Control Module																																																								
Y	2009	ALL	Chassis	Electronic Suspension Control																																																								
Y	2009	ALL	Body	Body Control Module																																																								
Y	2009	ALL	Body	CD Changer																																																								
Y	2009	ALL	Body	Digital Radio Receiver																																																								
Y	2009	ALL	Body	Driver Door Module																																																								
Y	2009	ALL	Body	Driver Door Switch																																																								
Y	2009	ALL	Body	Driver Position Module																																																								
Y	2009	ALL	Body	Folding Top Module																																																								
Y	2009	ALL	Body	Head Up Display																																																								
Y	2009	ALL	Body	HVAC Control Module																								V																																	
Y	2009	ALL	Body	Instrument Panel Cluster																V	V						V																																		
Y	2009	ALL	Body	Navigation Radio																																																								
Y	2009	ALL	Body	Passenger Door Module																																																								
Y	2009	ALL	Body	Radio																																																								
Y	2009	ALL	Body	Personal Audio Link Module																									V																															
Y	2009	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2009	ALL	Body	Steering Column Lock Module																																																								
Y	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																								
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																								
Y	2010	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																								
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																								
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																								
Y	2010	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																								
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																								
Y	2010	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																								
Y	2010	ALL	Chassis	Electronic Brake Control Module																																																								
Y	2010	ALL	Chassis	Electronic Suspension Control																																																								
Y	2010	ALL	Body	Body Control Module																																																								
Y	2010	ALL	Body	CD Changer																																																								
Y	2010	ALL	Body	Digital Radio Receiver																																																								
Y	2010	ALL	Body	Driver Door Module																																																								
Y	2010	ALL	Body	Driver Door Switch																																																								
Y	2010	ALL	Body	Driver Position Module																																																								
Y	2010	ALL	Body	Folding Top Module																																																								
Y	2010	ALL	Body	Head Up Display																																																								
Y	2010	ALL	Body	HVAC Control Module																								V																																	

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
Y	2010	ALL	Body	Instrument Panel Cluster																V	V							V																																
Y	2010	ALL	Body	Navigation Radio																																																								
Y	2010	ALL	Body	Passenger Door Module																																																								
Y	2010	ALL	Body	Radio																																																								
Y	2010	ALL	Body	Personal Audio Link Module																									V																																
Y	2010	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2010	ALL	Body	Steering Column Lock Module																																																								
Y	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																								
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																								
Y	2011	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																								
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																								
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																								
Y	2011	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																								
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																								
Y	2011	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																								
Y	2011	ALL	Chassis	Electronic Brake Control Module																																																								
Y	2011	ALL	Chassis	Electronic Suspension Control																																																								
Y	2011	ALL	Body	Body Control Module																																																								
Y	2011	ALL	Body	CD Changer																																																								
Y	2011	ALL	Body	Digital Radio Receiver																																																								
Y	2011	ALL	Body	Driver Door Module																																																								
Y	2011	ALL	Body	Driver Door Switch																																																								
Y	2011	ALL	Body	Driver Position Module																																																								
Y	2011	ALL	Body	Folding Top Module																																																								
Y	2011	ALL	Body	Head Up Display																																																								
Y	2011	ALL	Body	HVAC Control Module																									V																																
Y	2011	ALL	Body	Instrument Panel Cluster																V	V							V																																		
Y	2011	ALL	Body	Navigation Radio																																																								
Y	2011	ALL	Body	Passenger Door Module																																																								
Y	2011	ALL	Body	Radio																																																								
Y	2011	ALL	Body	Personal Audio Link Module																									V																																
Y	2011	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2011	ALL	Body	Steering Column Lock Module																																																								
Y	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																								
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																								
Y	2012	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																								
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																								
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																								
Y	2012	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																								
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																								
Y	2012	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																								
Y	2012	ALL	Chassis	Electronic Brake Control Module																																																								
Y	2012	ALL	Chassis	Electronic Suspension Control																																																								
Y	2012	ALL	Body	Body Control Module																																																								
Y	2012	ALL	Body	CD Changer																																																								
Y	2012	ALL	Body	Digital Radio Receiver																																																								
Y	2012	ALL	Body	Driver Door Module																																																								
Y	2012	ALL	Body	Driver Door Switch																																																								
Y	2012	ALL	Body	Driver Position Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
Y	2012	ALL	Body	Folding Top Module																																																								
Y	2012	ALL	Body	Head Up Display																																																								
Y	2012	ALL	Body	HVAC Control Module																								V																																
Y	2012	ALL	Body	Instrument Panel Cluster																V	V						V																																	
Y	2012	ALL	Body	Navigation Radio																																																								
Y	2012	ALL	Body	Passenger Door Module																																																								
Y	2012	ALL	Body	Radio																																																								
Y	2012	ALL	Body	Personal Audio Link Module																									V																																
Y	2012	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2012	ALL	Body	Steering Column Lock Module																																																								
Y	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Engine Control Module																																																								
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Exhaust Flow Control Module																																																								
Y	2013	ALL	Powertrain	(W)6.2L V8 LS3 Transmission Control Module																																																								
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Engine Control Module																																																								
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Exhaust Flow Control Module																																																								
Y	2013	ALL	Powertrain	(T)6.2L V8 LS9 Fuel Pump Control Module																																																								
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Engine Control Module																																																								
Y	2013	ALL	Powertrain	(E)7.0L V8 LS7 Exhaust Flow Control Module																																																								
Y	2013	ALL	Chassis	Electronic Brake Control Module																																																								
Y	2013	ALL	Chassis	Electronic Suspension Control																																																								
Y	2013	ALL	Body	Body Control Module																																																								
Y	2013	ALL	Body	CD Changer																																																								
Y	2013	ALL	Body	Digital Radio Receiver																																																								
Y	2013	ALL	Body	Driver Door Module																																																								
Y	2013	ALL	Body	Driver Door Switch																																																								
Y	2013	ALL	Body	Driver Position Module																																																								
Y	2013	ALL	Body	Folding Top Module																																																								
Y	2013	ALL	Body	Head Up Display																																																								
Y	2013	ALL	Body	HVAC Control Module																								V																																
Y	2013	ALL	Body	Instrument Panel Cluster																V	V						V																																	
Y	2013	ALL	Body	Navigation Radio																																																								
Y	2013	ALL	Body	Passenger Door Module																																																								
Y	2013	ALL	Body	Radio																																																								
Y	2013	ALL	Body	Personal Audio Link Module																									V																																
Y	2013	ALL	Body	Remote Control Door Lock Receiver																																																								
Y	2013	ALL	Body	Steering Column Lock Module																																																								
Y	2013	ALL	Body	Supplemental Inflatable Restraint																																																								
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																								
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																								
Y	2014	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																								
Y	2014	Corvette	Powertrain	Chassis Control Module																																																								
Y	2014	Corvette	Chassis	Electronic Brake Control Module																																																								
Y	2014	Corvette	Chassis	Parking Brake Control Module																																																								
Y	2014	Corvette	Chassis	Power Steering Control Module																																																								
Y	2014	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																								
Y	2014	Corvette	Chassis	Suspension Control Module																																																								
Y	2014	Corvette	Body	Body Control Module Convertible																																																								
Y	2014	Corvette	Body	Body Control Module Coupe																																																								
Y	2014	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
Y	2014	Corvette	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
Y	2014	Corvette	Body	Instrument Cluster																																																									
Y	2014	Corvette	Body	Radio/HVAC Control																																																									
Y	2014	Corvette	Body	Inside Rearview Mirror																																																									
Y	2014	Corvette	Body	Radio																																																									
Y	2014	Corvette	Body	Amplifier																																																									
Y	2014	Corvette	Body	Human Machine Interface Control Module																																																									
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																									
Y	2014	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																									
Y	2014	Corvette	Body	HVAC Control Module																																																									
Y	2014	Corvette	Body	Seat Memory Control Module - Passenger																																																									
Y	2014	Corvette	Body	Seat Memory Control Module - Driver																																																									
Y	2014	Corvette	Body	Folding Top Control Module																																																									
Y	2014	Corvette	Body	Keyless Entry Control Module																																																									
Y	2014	Corvette	Body	Steering Column Lock Control Module																																																									
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																									
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																									
Y	2015	Corvette	Powertrain	(7) 6.2L LT1 Transmission Control Module																																																									
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Automatic Transmission																																																									
Y	2015	Corvette	Powertrain	6.2L LT4 Engine Control Module Manual Transmission																																																									
Y	2015	Corvette	Powertrain	6.2L LT4 Transmission Control Module																																																									
Y	2015	Corvette	Powertrain	Chassis Control Module																																																									
Y	2015	Corvette	Chassis	Electronic Brake Control Module																																																									
Y	2015	Corvette	Chassis	Parking Brake Control Module																																																									
Y	2015	Corvette	Chassis	Power Steering Control Module																																																									
Y	2015	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																									
Y	2015	Corvette	Chassis	Suspension Control Module																																																									
Y	2015	Corvette	Body	Body Control Module Convertible																																																									
Y	2015	Corvette	Body	Body Control Module Coupe																																																									
Y	2015	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
Y	2015	Corvette	Body	Passenger Presence Module																																																									
Y	2015	Corvette	Body	Instrument Cluster																																																									
Y	2015	Corvette	Body	Radio/HVAC Control																																																									
Y	2015	Corvette	Body	Vehicle Performance Data Recorder																																																									
Y	2015	Corvette	Body	Inside Rearview Mirror																																																									
Y	2015	Corvette	Body	Radio																																																									
Y	2015	Corvette	Body	Amplifier																																																									
Y	2015	Corvette	Body	Human Machine Interface Control Module																																																									
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																									
Y	2015	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																									
Y	2015	Corvette	Body	HVAC Control Module																																																									
Y	2015	Corvette	Body	Seat Memory Control Module - Passenger																																																									
Y	2015	Corvette	Body	Seat Memory Control Module - Driver																																																									
Y	2015	Corvette	Body	Folding Top Control Module																																																									
Y	2015	Corvette	Body	Keyless Entry Control Module																																																									
Y	2015	Corvette	Body	Steering Column Lock Control Module																																																									
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Automatic Transmission																																																									
Y	2016	Corvette	Powertrain	(7) 6.2L LT1 Engine Control Module Manual Transmission																																																									
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Automatic Transmission																																																									
Y	2016	Corvette	Powertrain	(6) 6.2L LT4 Engine Control Module Manual Transmission																																																									
Y	2016	Corvette	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
Y	2016	Corvette	Powertrain	Rear Differential Clutch Control Module																																																									
Y	2016	Corvette	Chassis	Electronic Brake Control Module																																																										
Y	2016	Corvette	Chassis	Parking Brake Control Module																																																										
Y	2016	Corvette	Chassis	Power Steering Control Module																																																										
Y	2016	Corvette	Chassis	Steering Wheel Angle Sensor Module																																																										
Y	2016	Corvette	Chassis	Suspension Control Module																																																										
Y	2016	Corvette	Body	Body Control Module																																																										
Y	2016	Corvette	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Y	2016	Corvette	Body	Passenger Presence Module																																																										
Y	2016	Corvette	Body	Instrument Cluster																																																										
Y	2016	Corvette	Body	Radio/HVAC Control																																																										
Y	2016	Corvette	Body	Vehicle Performance Data Recorder																																																										
Y	2016	Corvette	Body	Video Processing Control Module																																																										
Y	2016	Corvette	Body	Inside Rearview Mirror																																																										
Y	2016	Corvette	Body	Radio																																																										
Y	2016	Corvette	Body	Amplifier																																																										
Y	2016	Corvette	Body	Human Machine Interface Control Module																																																										
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 9.7																																																										
Y	2016	Corvette	Body	Telematics Communication Interface Control Module Version 10																																																										
Y	2016	Corvette	Body	HVAC Control Module																																																										
Y	2016	Corvette	Body	Liftgate Control Module																																																										
Y	2016	Corvette	Body	Seat Memory Control Module - Passenger																																																										
Y	2016	Corvette	Body	Seat Memory Control Module - Driver																																																										
Y	2016	Corvette	Body	Folding Top Control Module																																																										
Y	2016	Corvette	Body	Keyless Entry Control Module																																																										
Y	2016	Corvette	Body	Steering Column Lock Control Module																																																										
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
Y	2016	Cruze	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Automatic Transmission																																																										
Y	2016	Cruze	Powertrain	1.4L LEX Engine Control Module Manual Transmission																																																										
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Automatic Transmission																																																										
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Engine Control Module Manual Transmission																																																										
Y	2016	Cruze	Powertrain	(D) 1.5L L3G Transmission Control Module																																																										
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Automatic Transmission																																																										
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Engine Control Module Manual Transmission																																																										
Y	2016	Cruze	Powertrain	(T) 1.5L LFV Transmission Control Module																																																										
Y	2016	Cruze	Chassis	Electronic Brake Control Module																																																										
Y	2016	Cruze	Chassis	Distance Sensing Cruise Control Module																																																										
Y	2016	Cruze	Chassis	Power Steering Control Module																																																										
Y	2016	Cruze	Chassis	Steering Wheel Angle Sensor Module																																																										
Y	2016	Cruze	Body	Body Control Module																																																										
Y	2016	Cruze	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
Y	2016	Cruze	Body	Passenger Presence Module																																																										
Y	2016	Cruze	Body	Instrument Cluster																																																										
Y	2016	Cruze	Body	Radio Controls																																																										
Y	2016	Cruze	Body	HVAC Controls																																																										
Y	2016	Cruze	Body	Trailer Interface Control Module																																																										
Y	2016	Cruze	Body	Radio Base (IO3 IO7)																																																										
Y	2016	Cruze	Body	Radio (IOA)																																																										
Y	2016	Cruze	Body	Radio (IOB)																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
Y	2016	Cruze	Body	Radio Uplevel (IO4 IO5 IO6)																																																								
Y	2016	Cruze	Body	Amplifier																																																								
Y	2016	Cruze	Body	Multimedia Player Interface Module																																																								
Y	2016	Cruze	Body	Human Machine Interface Control Module																																																								
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 9.7																																																								
Y	2016	Cruze	Body	Telematics Communication Interface Control Module Version 10																																																								
Y	2016	Cruze	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
Y	2016	Cruze	Body	HVAC Auto Control Single Zone (C68)																																																								
Y	2016	Cruze	Body	HVAC Manual Control Heater Only (C42)																																																								
Y	2016	Cruze	Body	HVAC Manual Control Single Zone (C67)																																																								
Y	2016	Cruze	Body	Keyless Entry Control Module																																																								
Y	2016	Cruze	Body	Right Side Object Detection Control Module																																																								
Y	2016	Cruze	Body	Left Side Object Detection Control Module																																																								
Y	2016	Cruze	Body	Parking Assist Control Module																																																								
Y	2016	Cruze	Body	Frontview Camera Module																																																								
Y	2016	Cruze	Body	Steering Column Lock Control Module																																																								
Y	2016	Cruze	Body	Long Range Radar Sensor Module																																																								
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																											V	V																												
Z	2004	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																											V	V																												
Z	2004	ALL	Powertrain	(8)3.5L V6 LX9 Transmission Control Module																																																								
Z	2004	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2004	ALL	Chassis	Power Steering Control Module																													V	V																										
Z	2004	ALL	Body	Body Control Module																																																								
Z	2004	ALL	Body	Digital Radio Receiver																																																								
Z	2004	ALL	Body	HVAC Control Module																																																								
Z	2004	ALL	Body	Instrument Panel Cluster																																																								
Z	2004	ALL	Body	Radio																																																								
Z	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2004	ALL	Body	Theft Deterrent Module																															V																									
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																											V	V																												
Z	2005	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
Z	2005	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																V																								
Z	2005	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2005	ALL	Chassis	Power Steering Control Module																													V	V																										
Z	2005	ALL	Body	Body Control Module																																																								
Z	2005	ALL	Body	Digital Radio Receiver																																																								
Z	2005	ALL	Body	HVAC Control Module																																																								
Z	2005	ALL	Body	Instrument Panel Cluster																																																								
Z	2005	ALL	Body	Radio																																																								
Z	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2005	ALL	Body	Theft Deterrent Module																															V																									
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																											V	V																												
Z	2006	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																																																								
Z	2006	ALL	Powertrain	(8)3.5L V6 LX9 Engine Control Module																																V																								
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																V																								
Z	2006	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
Z	2006	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2006	ALL	Chassis	Power Steering Control Module																													V	V																										
Z	2006	ALL	Body	Body Control Module																																																								
Z	2006	ALL	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
Z	2006	ALL	Body	HVAC Control Module																																																								
Z	2006	ALL	Body	Instrument Panel Cluster																																																								
Z	2006	ALL	Body	Radio																																																								
Z	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2006	ALL	Body	Theft Deterrent Module																															V																									
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
Z	2007	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																					V	V										V																								
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																															V		V																							
Z	2007	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																					V	V										V																								
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																															V		V																							
Z	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
Z	2007	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2007	ALL	Chassis	Power Steering Control Module																													V	V																										
Z	2007	ALL	Body	Body Control Module																																		V																						
Z	2007	ALL	Body	Digital Radio Receiver																																																								
Z	2007	ALL	Body	Disc Player and Video Display																																																								
Z	2007	ALL	Body	HVAC Control Module																																																								
Z	2007	ALL	Body	Instrument Panel Cluster																																																								
Z	2007	ALL	Body	Radio																																																								
Z	2007	ALL	Body	Remote Control Door Lock Receiver																																			V																					
Z	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2007	ALL	Body	Theft Deterrent Module																															V																									
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Engine Control Module																																																								
Z	2008	ALL	Powertrain	(F)2.2L L4 L61 Transmission Control Module																					V	V										V																								
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																								
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																								
Z	2008	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																					V	V										V																								
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																															V																									
Z	2008	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																					V	V										V																								
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																															V					V																				
Z	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
Z	2008	ALL	Chassis	Electronic Brake Control Module																																																								
Z	2008	ALL	Chassis	Power Steering Control Module																													V	V																										
Z	2008	ALL	Body	Body Control Module Classic																																		V																						
Z	2008	ALL	Body	Body Control Module Malibu																																		V			V																			
Z	2008	ALL	Body	Digital Radio Receiver																																																								
Z	2008	ALL	Body	Disc Player and Video Display																																																								
Z	2008	ALL	Body	HVAC Control Module Classic																																																								
Z	2008	ALL	Body	HVAC Control Module Malibu																																																								
Z	2008	ALL	Body	Instrument Panel Cluster Classic																																																								
Z	2008	ALL	Body	Instrument Panel Cluster Malibu																																																								
Z	2008	ALL	Body	Radio																																																								
Z	2008	ALL	Body	Remote Control Door Lock Receiver																																			V																					
Z	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2008	ALL	Body	Theft Deterrent Module																															V																									
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																								
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																								
Z	2009	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																								
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module with Air Pump																															V						V																			
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module without Air Pump																															V						V																			
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission With Tap Shift																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
Z	2009	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Without Tap Shift																																																							
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																															V							V																	
Z	2009	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																							
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																															V					V		V																	
Z	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																							
Z	2009	ALL	Chassis	Electronic Brake Control Module																																																							
Z	2009	ALL	Chassis	Power Steering Control Module																													V	V																										
Z	2009	ALL	Body	Body Control Module																																		V			V																	
Z	2009	ALL	Body	Digital Radio Receiver																																																						
Z	2009	ALL	Body	Disc Player and Video Display																																																						
Z	2009	ALL	Body	HVAC Control Module																																																						
Z	2009	ALL	Body	Instrument Panel Cluster																																																						
Z	2009	ALL	Body	Personal Audio Link Module																																																						
Z	2009	ALL	Body	Radio																																																						
Z	2009	ALL	Body	Supplemental Inflatable Restraint																																																						
Z	2009	ALL	Body	Theft Deterrent Module																															V																							
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Engine Control Module																																																						
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 6 Speed																																																						
Z	2010	ALL	Powertrain	(B)2.4L L4 LE5 Transmission Control Module 4 Speed																																																						
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Engine Control Module																																																						
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 6 Speed																																																						
Z	2010	ALL	Powertrain	(0)2.4L L4 LE9 Transmission Control Module 4 Speed																																																						
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Engine Control Module																															V							V																	
Z	2010	ALL	Powertrain	(N)3.5L V6 LZ4 Transmission Control Module																																																						
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Engine Control Module																															V							V																	
Z	2010	ALL	Powertrain	(K)3.5L V6 LZE Transmission Control Module																																																						
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																															V					V		V																	
Z	2010	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																						
Z	2010	ALL	Chassis	Electronic Brake Control Module																																																						
Z	2010	ALL	Chassis	Power Steering Control Module																													V	V																										
Z	2010	ALL	Body	Body Control Module																																		V			V																	
Z	2010	ALL	Body	Digital Radio Receiver																																																						
Z	2010	ALL	Body	HVAC Control Module																																																						
Z	2010	ALL	Body	Instrument Panel Cluster																																																						
Z	2010	ALL	Body	Personal Audio Link Module																																																						
Z	2010	ALL	Body	Radio																																																						
Z	2010	ALL	Body	Supplemental Inflatable Restraint																																																						
Z	2010	ALL	Body	Theft Deterrent Module																															V																							
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																						
Z	2011	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																						
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																						
Z	2011	ALL	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																						
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																															V					V		V																	
Z	2011	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																						
Z	2011	ALL	Chassis	Electronic Brake Control Module																																																						
Z	2011	ALL	Chassis	Power Steering Control Module																													V	V																										
Z	2011	ALL	Body	Body Control Module																																		V			V																	
Z	2011	ALL	Body	Digital Radio Receiver																																																						
Z	2011	ALL	Body	HVAC Control Module																																																						
Z	2011	ALL	Body	Instrument Panel Cluster																																																						
Z	2011	ALL	Body	Personal Audio Link Module																																																						

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
Z	2011	ALL	Body	Radio																																																								
Z	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
Z	2011	ALL	Body	Theft Deterrent Module																															V																									
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Engine Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(0)2.4L L4 LE5 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																V				V		V																		
Z	2012	Malibu (Seventh Gen)	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Chassis	Electronic Brake Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Chassis	Power Steering Control Module																													V	V																										
Z	2012	Malibu (Seventh Gen)	Body	Body Control Module																																		V			V																			
Z	2012	Malibu (Seventh Gen)	Body	Digital Radio Receiver																																																								
Z	2012	Malibu (Seventh Gen)	Body	HVAC Control Module																																																								
Z	2012	Malibu (Seventh Gen)	Body	Instrument Panel Cluster																																																								
Z	2012	Malibu (Seventh Gen)	Body	Personal Audio Link Module																																																								
Z	2012	Malibu (Seventh Gen)	Body	Radio																																																								
Z	2012	Malibu (Seventh Gen)	Body	Supplemental Inflatable Restraint																																																								
Z	2012	Malibu (Seventh Gen)	Body	Theft Deterrent Module																															V																									
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Fuel Injector Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBN Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LBS Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Fuel Pump Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	2.0L LTD Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Fuel Pump Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Powertrain	Rear Differential Clutch Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Electronic Brake Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Parking Brake Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Power Steering Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Steering Wheel Angle Sensor Module																																																								
Z	2012	Malibu (Eighth Gen)	Chassis	Suspension Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
Z	2012	Malibu (Eighth Gen)	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																								
Z	2012	Malibu (Eighth Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																								
Z	2012	Malibu (Eighth Gen)	Body	Passenger Presence Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
Z	2012	Malibu (Eighth Gen)	Body	Instrument Cluster																																																								
Z	2012	Malibu (Eighth Gen)	Body	Head-Up Display Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Headlamp Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Radio																																																								
Z	2012	Malibu (Eighth Gen)	Body	Digital Radio Receiver Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Multimedia Player Interface Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Mobile Telephone Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Dual (CJ2)																																																								
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Auto Single (C68)																																																								
Z	2012	Malibu (Eighth Gen)	Body	HVAC Control Module Manual Single (C67)																																																								
Z	2012	Malibu (Eighth Gen)	Body	Rear Seat Heating Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Keyless Entry Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Right Side Object Detection Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Left Side Object Detection Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Parking Assist Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Vehicle Direction Camera Control Module																																																								
Z	2012	Malibu (Eighth Gen)	Body	Steering Column Lock Control Module																																																								
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Engine Control Module																																																								
Z	2016	Malibu	Powertrain	(T) 1.5L LFV Transmission Control Module																																																								
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Engine Control Module																																																								
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 1																																																								
Z	2016	Malibu	Powertrain	(U) 1.8L LKN Drive Motor Control Module 2																																																								
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module																																																								
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 6 Speed (MNM)																																																								
Z	2016	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module 8 Speed (MRC)																																						V																		
Z	2016	Malibu	Chassis	Electronic Brake Control Module																																																								
Z	2016	Malibu	Chassis	Brake Booster Control Module																																																								
Z	2016	Malibu	Chassis	Power Steering Control Module																																																								
Z	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
Z	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																								V																
Z	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
Z	2016	Malibu	Body	Passenger Presence Module																																																								
Z	2016	Malibu	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																								
Z	2016	Malibu	Body	Instrument Cluster Enhanced Monochrome Driver Info Center (UDC)																																																								
Z	2016	Malibu	Body	Radio Controls																																																								
Z	2016	Malibu	Body	HVAC Controls																																																								
Z	2016	Malibu	Body	Active Safety Control Module																																																								
Z	2016	Malibu	Body	Headlamp Control Module																																																								
Z	2016	Malibu	Body	Radio Base																																																								
Z	2016	Malibu	Body	Radio (IOA)																																																								
Z	2016	Malibu	Body	Radio Uplevel (IO4 IO5 IO6)																																																								
Z	2016	Malibu	Body	Amplifier																																																								
Z	2016	Malibu	Body	Human Machine Interface Control Module																																																								
Z	2016	Malibu	Body	Navigation Control Module																																																								
Z	2016	Malibu	Body	Mobile Telephone Control Module																																																								
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																								
Z	2016	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																								
Z	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																								
Z	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																								
Z	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																								
Z	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
Z	2016	Malibu	Body	Electric A/C Compressor Control Module																																																									
Z	2016	Malibu	Body	Seat Memory Control Module - Driver																																																										
Z	2016	Malibu	Body	Keyless Entry Control Module																																																										
Z	2016	Malibu	Body	Right Side Object Detection Control Module																																																										
Z	2016	Malibu	Body	Left Side Object Detection Control Module																																																										
Z	2016	Malibu	Body	Parking Assist Control Module																																																										
Z	2016	Malibu	Body	Frontview Camera Module																																																										
Z	2016	Malibu	Body	Frontview Camera Module																																																										
Z	2016	Malibu	Body	Steering Column Lock Control Module																																																										
Z	2016	Malibu	Body	Long Range Radar Sensor Module																																																										
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LBY Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.0L LTD Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Hybrid Powertrain Control Module																																																										
1	2013	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Fuel Pump Control Module																																																										
1	2013	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
1	2013	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
1	2013	Malibu	Chassis	Electronic Brake Control Module																																																										
1	2013	Malibu	Chassis	Parking Brake Control Module																																																										
1	2013	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2013	Malibu	Chassis	Power Steering Control Module																																																										
1	2013	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2013	Malibu	Chassis	Suspension Control Module																																																										
1	2013	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
1	2013	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2013	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																								
1	2013	Malibu	Body	Passenger Presence Module																																																								
1	2013	Malibu	Body	Instrument Cluster																																																								
1	2013	Malibu	Body	Headlamp Control Module																																																								
1	2013	Malibu	Body	Radio																																																								
1	2013	Malibu	Body	Digital Radio Receiver Control Module																																																								
1	2013	Malibu	Body	Multimedia Player Interface Module																																																								
1	2013	Malibu	Body	Mobile Telephone Control Module																																																								
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																								
1	2013	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																								
1	2013	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																								
1	2013	Malibu	Body	HVAC Control Module Auto Single (C68)																																																								
1	2013	Malibu	Body	HVAC Control Module Manual Single (C67)																																																								
1	2013	Malibu	Body	Rear Seat Heating Control Module																																																								
1	2013	Malibu	Body	Keyless Entry Control Module																																																								
1	2013	Malibu	Body	Parking Assist Control Module																																																								
1	2013	Malibu	Body	Vehicle Direction Camera Control Module																																																								
1	2013	Malibu	Body	Steering Column Lock Control Module																																																								
1	2013	Malibu	Body	Battery Energy Control Module																																																								
1	2014	Impala	Powertrain	(R) 2.4L LUK Engine Control Module																																																								
1	2014	Impala	Powertrain	(R) 2.4L LUK Transmission Control Module																																																								
1	2014	Impala	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																								
1	2014	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																								
1	2014	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																								
1	2014	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
1	2014	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																								
1	2014	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																								
1	2014	Impala	Chassis	Electronic Brake Control Module																																																								
1	2014	Impala	Chassis	Distance Sensing Cruise Control Module																																																								
1	2014	Impala	Chassis	Parking Brake Control Module																																																								
1	2014	Impala	Chassis	Power Steering Control Module																																																								
1	2014	Impala	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2014	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
1	2014	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
1	2014	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2014	Impala	Body	Passenger Presence Module																																																								
1	2014	Impala	Body	Instrument Cluster																																																								
1	2014	Impala	Body	Radio Control																																																								
1	2014	Impala	Body	HVAC Control																																																								
1	2014	Impala	Body	Radio																																																								
1	2014	Impala	Body	Amplifier																																																								
1	2014	Impala	Body	Human Machine Interface Control Module																																																								
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 9																																																								
1	2014	Impala	Body	Telematics Communication Interface Control Module Version 10																																																								
1	2014	Impala	Body	HVAC Control Module																																																								
1	2014	Impala	Body	Keyless Entry Control Module																																																								
1	2014	Impala	Body	Right Side Object Detection Control Module																																																								
1	2014	Impala	Body	Left Side Object Detection Control Module																																																								
1	2014	Impala	Body	Parking Assist Control Module																																																								
1	2014	Impala	Body	Frontview Camera Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2014	Impala	Body	Steering Column Lock Control Module																																																								
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
1	2014	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
1	2014	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																								
1	2014	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																								
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																								
1	2014	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																								
1	2014	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																								
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																								
1	2014	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																								
1	2014	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																								
1	2014	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																								
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																								
1	2014	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																								
1	2014	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																								
1	2014	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
1	2014	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
1	2014	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																								
1	2014	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																								
1	2014	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																								
1	2014	Malibu	Powertrain	(R) 2.4L LUK Drive Motor Control Module																																																								
1	2014	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																								
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																																								
1	2014	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																								
1	2014	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																								
1	2014	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																								
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
1	2014	Malibu	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
1	2014	Malibu	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
1	2014	Malibu	Chassis	Electronic Brake Control Module																																																								
1	2014	Malibu	Chassis	Parking Brake Control Module																																																								
1	2014	Malibu	Chassis	Multi-Axis Acceleration Sensor Module																																																								
1	2014	Malibu	Chassis	Power Steering Control Module																																																								
1	2014	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2014	Malibu	Chassis	Suspension Control Module																																																								
1	2014	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
1	2014	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 3																																																								
1	2014	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module Version 4																																																								
1	2014	Malibu	Body	Passenger Presence Module																																																								
1	2014	Malibu	Body	Instrument Cluster																																																								
1	2014	Malibu	Body	Headlamp Control Module																																																								
1	2014	Malibu	Body	Radio																																																								
1	2014	Malibu	Body	Digital Radio Receiver Control Module																																																								
1	2014	Malibu	Body	Multimedia Player Interface Module																																																								
1	2014	Malibu	Body	Mobile Telephone Control Module																																																								
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 9																																																								
1	2014	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																								
1	2014	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																								
1	2014	Malibu	Body	HVAC Control Module Auto Single (C68)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2014	Malibu	Body	HVAC Control Module Manual Single (C67)																																																									
1	2014	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																									
1	2014	Malibu	Body	Rear Seat Heating Control Module																																																									
1	2014	Malibu	Body	Keyless Entry Control Module																																																									
1	2014	Malibu	Body	Left Side Object Detection Control Module																																																									
1	2014	Malibu	Body	Parking Assist Control Module																																																									
1	2014	Malibu	Body	Frontview Camera Module																																																									
1	2014	Malibu	Body	Steering Column Lock Control Module																																																									
1	2015	Impala	Powertrain	(L) 2.5L LKW Engine Control Module																																																									
1	2015	Impala	Powertrain	(L) 2.5L LKW Transmission Control Module																																																									
1	2015	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																									
1	2015	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																									
1	2015	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
1	2015	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump																																																									
1	2015	Impala	Powertrain	Chassis Control Module Version Fuel Pump and Active Grille Air Shutter																																																									
1	2015	Impala	Chassis	Electronic Brake Control Module																																																									
1	2015	Impala	Chassis	Distance Sensing Cruise Control Module																																																									
1	2015	Impala	Chassis	Parking Brake Control Module																																																									
1	2015	Impala	Chassis	Power Steering Control Module																																																									
1	2015	Impala	Chassis	Power Steering Control Module																																																									
1	2015	Impala	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2015	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
1	2015	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
1	2015	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2015	Impala	Body	Passenger Presence Module																																																									
1	2015	Impala	Body	Instrument Cluster																																																									
1	2015	Impala	Body	Radio Control																																																									
1	2015	Impala	Body	HVAC Control																																																									
1	2015	Impala	Body	Radio																																																									
1	2015	Impala	Body	Amplifier																																																									
1	2015	Impala	Body	Human Machine Interface Control Module																																																									
1	2015	Impala	Body	Telematics Communication Interface Control Module																																																									
1	2015	Impala	Body	HVAC Control Module																																																									
1	2015	Impala	Body	Keyless Entry Control Module																																																									
1	2015	Impala	Body	Right Side Object Detection Control Module																																																									
1	2015	Impala	Body	Left Side Object Detection Control Module																																																									
1	2015	Impala	Body	Parking Assist Control Module																																																									
1	2015	Impala	Body	Frontview Camera Module																																																									
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	2.0L LBN Fuel Injector Control Module																																																									
1	2015	Malibu	Powertrain	2.0L LBN Chassis Control Module																																																									
1	2015	Malibu	Powertrain	2.0L LBN Transmission Control Module																																																									
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	2.0L LBS Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	2.0L LBS Chassis Control Module																																																									
1	2015	Malibu	Powertrain	2.0L LBS Transmission Control Module																																																									
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Automatic Transmission																																																									
1	2015	Malibu	Powertrain	2.0L LTD Engine Control Module Manual Transmission																																																									
1	2015	Malibu	Powertrain	2.0L LTD Chassis Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2015	Malibu	Powertrain	2.0L LTD Transmission Control Module																																																								
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																								
1	2015	Malibu	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																								
1	2015	Malibu	Powertrain	(X) 2.0L LTG Chassis Control Module																																																								
1	2015	Malibu	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
1	2015	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
1	2015	Malibu	Powertrain	2.4L LE9 Chassis Control Module																																																								
1	2015	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																								
1	2015	Malibu	Powertrain	(R) 2.4L LUK Engine Control Module																																																								
1	2015	Malibu	Powertrain	(R) 2.4L LUK Chassis Control Module																																																								
1	2015	Malibu	Powertrain	(R) 2.4L LUK Transmission Control Module																																																								
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Automatic Transmission																																									V															
1	2015	Malibu	Powertrain	(L) 2.5L LKW Engine Control Module Manual Transmission																																																								
1	2015	Malibu	Powertrain	(L) 2.5L LKW Chassis Control Module																																																								
1	2015	Malibu	Powertrain	(L) 2.5L LKW Transmission Control Module																																																								
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Automatic Transmission																																																								
1	2015	Malibu	Powertrain	3.0L LFW Engine Control Module Manual Transmission																																																								
1	2015	Malibu	Powertrain	3.0L LFW Chassis Control Module																																																								
1	2015	Malibu	Powertrain	3.0L LFW Transmission Control Module																																																								
1	2015	Malibu	Powertrain	Rear Differential Clutch Control Module																																																								
1	2015	Malibu	Chassis	Electronic Brake Control Module																																																								
1	2015	Malibu	Chassis	Parking Brake Control Module																																																								
1	2015	Malibu	Chassis	Power Steering Control Module																																																								
1	2015	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2015	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
1	2015	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
1	2015	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2015	Malibu	Body	Passenger Presence Module																																																								
1	2015	Malibu	Body	Instrument Cluster																																																								
1	2015	Malibu	Body	Headlamp Control Module																																																								
1	2015	Malibu	Body	Radio																																																								
1	2015	Malibu	Body	Digital Radio Receiver Control Module																																																								
1	2015	Malibu	Body	Multimedia Player Interface Module																																																								
1	2015	Malibu	Body	Mobile Telephone Control Module																																																								
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 9.7																																																								
1	2015	Malibu	Body	Telematics Communication Interface Control Module Version 10																																																								
1	2015	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																								
1	2015	Malibu	Body	HVAC Control Module Auto Single (C68)																																																								
1	2015	Malibu	Body	HVAC Control Module Manual Single (C67)																																																								
1	2015	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																								
1	2015	Malibu	Body	Front Seat Heating Control Module																																																								
1	2015	Malibu	Body	Rear Seat Heating Control Module																																																								
1	2015	Malibu	Body	Keyless Entry Control Module																																																								
1	2015	Malibu	Body	Left Side Object Detection Control Module																																																								
1	2015	Malibu	Body	Parking Assist Control Module																																																								
1	2015	Malibu	Body	Frontview Camera Module																																																								
1	2015	Malibu	Body	Steering Column Lock Control Module																																																								
1	2015	Malibu (LSG)	Powertrain	1.6L LLU Engine Control Module																																										V	V													
1	2015	Malibu (LSG)	Powertrain	Transmission Control Module																																																								
1	2015	Malibu (LSG)	Powertrain	Rear Differential Clutch Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2015	Malibu (LSG)	Chassis	Electronic Brake Control Module																																																								
1	2015	Malibu (LSG)	Chassis	Parking Brake Control Module																																																								
1	2015	Malibu (LSG)	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2015	Malibu (LSG)	Chassis	Suspension Control Module																																																								
1	2015	Malibu (LSG)	Body	Body Control Module																																																								
1	2015	Malibu (LSG)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2015	Malibu (LSG)	Body	Instrument Cluster																																																								
1	2015	Malibu (LSG)	Body	Headlamp Control Module																																																								
1	2015	Malibu (LSG)	Body	Radio																																																								
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 9.7																																																								
1	2015	Malibu (LSG)	Body	Telematics Communication Interface Control Module Version 10																																																								
1	2015	Malibu (LSG)	Body	HVAC Control Module																																																								
1	2015	Malibu (LSG)	Body	Front Seat Heating Control Module																																																								
1	2015	Malibu (LSG)	Body	Keyless Entry Control Module																																																								
1	2015	Malibu (LSG)	Body	Left Side Object Detection Control Module																																																								
1	2015	Malibu (LSG)	Body	Parking Assist Control Module																																																								
1	2015	Malibu (LSG)	Body	Frontview Camera Module																																																								
1	2015	Malibu (LSG)	Body	Steering Column Lock Control Module																																																								
1	2016	Impala	Powertrain	(A) 2.5L LCV Engine Control Module																																																								
1	2016	Impala	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
1	2016	Impala	Powertrain	(N) 3.6L LFR Engine Control Module																																																								
1	2016	Impala	Powertrain	(N) 3.6L LFR Transmission Control Module																																																								
1	2016	Impala	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
1	2016	Impala	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
1	2016	Impala	Powertrain	Chassis Control Module																																																								
1	2016	Impala	Chassis	Electronic Brake Control Module																																																								
1	2016	Impala	Chassis	Distance Sensing Cruise Control Module																																																								
1	2016	Impala	Chassis	Parking Brake Control Module																																																								
1	2016	Impala	Chassis	Power Steering Control Module																																																								
1	2016	Impala	Chassis	Power Steering Control Module																																																								
1	2016	Impala	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2016	Impala	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
1	2016	Impala	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
1	2016	Impala	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2016	Impala	Body	Passenger Presence Module																																																								
1	2016	Impala	Body	Instrument Cluster																																																								
1	2016	Impala	Body	Radio Control																																																								
1	2016	Impala	Body	HVAC Control																																																								
1	2016	Impala	Body	Radio																																																								
1	2016	Impala	Body	Amplifier																																																								
1	2016	Impala	Body	Human Machine Interface Control Module																																																								
1	2016	Impala	Body	Navigation Control Module																																																								
1	2016	Impala	Body	Telematics Communication Interface Control Module																																																								
1	2016	Impala	Body	HVAC Control Module																																																								
1	2016	Impala	Body	Seat Memory Control Module - Driver																																																								
1	2016	Impala	Body	Keyless Entry Control Module																																																								
1	2016	Impala	Body	Right Side Object Detection Control Module																																																								
1	2016	Impala	Body	Left Side Object Detection Control Module																																																								
1	2016	Impala	Body	Parking Assist Control Module																																																								
1	2016	Impala	Body	Frontview Camera Module																																																								
1	2016	Malibu	Powertrain	2.0L LTD Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
1	2016	Malibu	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
1	2016	Malibu	Powertrain	2.4L LE9 Transmission Control Module																																																								
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
1	2016	Malibu	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
1	2016	Malibu	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
1	2016	Malibu	Powertrain	Fuel Injector Control Module																																																								
1	2016	Malibu	Powertrain	Chassis Control Module																																																								
1	2016	Malibu	Chassis	Electronic Brake Control Module																																																								
1	2016	Malibu	Chassis	Parking Brake Control Module																																																								
1	2016	Malibu	Chassis	Power Steering Control Module																																																								
1	2016	Malibu	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2016	Malibu	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
1	2016	Malibu	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
1	2016	Malibu	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2016	Malibu	Body	Passenger Presence Module																																																								
1	2016	Malibu	Body	Instrument Cluster																																																								
1	2016	Malibu	Body	Headlamp Control Module																																																								
1	2016	Malibu	Body	Radio																																																								
1	2016	Malibu	Body	Digital Radio Receiver Control Module																																																								
1	2016	Malibu	Body	Multimedia Player Interface Module																																																								
1	2016	Malibu	Body	Mobile Telephone Control Module																																																								
1	2016	Malibu	Body	Telematics Communication Interface Control Module																																																								
1	2016	Malibu	Body	HVAC Control Module Auto Dual (CJ2)																																																								
1	2016	Malibu	Body	HVAC Control Module Auto Single (C68)																																																								
1	2016	Malibu	Body	HVAC Control Module Manual Single (C67)																																																								
1	2016	Malibu	Body	HVAC Control Module Semi Auto Single (C4P)																																																								
1	2016	Malibu	Body	Seat Memory Control Module																																																								
1	2016	Malibu	Body	Front Seat Heating Control Module																																																								
1	2016	Malibu	Body	Rear Seat Heating Control Module																																																								
1	2016	Malibu	Body	Keyless Entry Control Module																																																								
1	2016	Malibu	Body	Left Side Object Detection Control Module																																																								
1	2016	Malibu	Body	Parking Assist Control Module																																																								
1	2016	Malibu	Body	Frontview Camera Module																																																								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V															
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V														
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit	V	V																	V	V									V	V	V	V	V	V																		
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V													
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V													
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit	V	V																	V	V									V	V	V	V	V	V																		
J	2013	Encore	Powertrain	Fuel Pump Control Module	V	V																	V	V						V		V																								
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module	V	V																		V																						V										
J	2013	Encore	Chassis	Electronic Brake Control Module	V	V																	V	V												V											V	V	V	V	V	V				
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																															V	V
J	2013	Encore	Chassis	Power Steering Control Module	V	V																		V																															
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module	V																			V																															
J	2013	Encore	Body	Body Control Module	V	V																	V	V																															
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																															
J	2013	Encore	Body	Passenger Presence Module	V	V																		V																															
J	2013	Encore	Body	Instrument Cluster	V	V																	V	V																															
J	2013	Encore	Body	Radio	V	V																	V	V																															
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9	V	V																	V	V																															
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																															
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)	V	V																	V	V																															
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)	V	V																	V	V																															
J	2013	Encore	Body	Seat Memory Control Module	V																																																	
J	2013	Encore	Body	Front Seat Heating Control Module	V	V																	V	V																															
J	2013	Encore	Body	Parking Assist Control Module	V	V																	V	V																															
J	2013	Encore	Body	Frontview Camera Module	V	V																	V	V																															
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V													
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V													
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit	V	V																	V	V									V	V	V	V	V	V																		
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V														V													
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																		V	V			V	V	V	V													V	V													
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit	V	V																	V	V									V	V	V	V	V	V																		
J	2014	Encore	Powertrain	Chassis Control Module	V	V																	V	V						V		V																								
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module	V	V																		V																						V										
J	2014	Encore	Chassis	Electronic Brake Control Module	V	V																	V	V												V											V	V	V	V	V	V				
J	2014	Encore	Chassis	Power Steering Control Module	V	V																		V																															
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module	V																			V																															
J	2014	Encore	Body	Body Control Module	V	V																	V	V																															
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																															
J	2014	Encore	Body	Passenger Presence Module	V	V																		V																															
J	2014	Encore	Body	Instrument Cluster	V	V																	V	V																															
J	2014	Encore	Body	Radio Other	V	V																	V	V																															
J	2014	Encore	Body	Radio (UF7)	V	V																	V	V																															
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9	V	V																	V	V																															
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																															
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)	V	V																	V	V																															
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)	V	V																	V	V																															
J	2014	Encore	Body	Seat Memory Control Module	V																																																	
J	2014	Encore	Body	Front Seat Heating Control Module	V	V																	V	V																															
J	2014	Encore	Body	Left Side Object Detection Control Module	V																		V	V																															
J	2014	Encore	Body	Parking Assist Control Module	V	V																	V	V																															
J	2014	Encore	Body	Frontview Camera Module	V	V																	V	V																															

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V															
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit	V	V																	V	V										V	V	V	V	V	V																				
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V														
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit	V	V																	V	V										V	V	V	V	V	V																				
J	2015	Encore	Powertrain	Chassis Control Module	V	V																	V	V							V		V																										
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module	V	V																		V																							V											
J	2015	Encore	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V						
J	2015	Encore	Chassis	Power Steering Control Module	V	V																		V																																		
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module	V																			V																																		
J	2015	Encore	Body	Body Control Module	V	V																	V	V																																		
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
J	2015	Encore	Body	Passenger Presence Module	V	V																		V																																		
J	2015	Encore	Body	Instrument Cluster	V	V																	V	V																																		
J	2015	Encore	Body	Radio Other	V	V																	V	V																																		
J	2015	Encore	Body	Radio (UF7)	V	V																	V	V																																		
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7	V	V																	V	V																																		
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																		
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)	V	V																	V	V																																		
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)	V	V																	V	V																																		
J	2015	Encore	Body	Seat Memory Control Module	V																																																				
J	2015	Encore	Body	Front Seat Heating Control Module	V	V																	V	V																																		
J	2015	Encore	Body	Left Side Object Detection Control Module	V																		V	V																																		
J	2015	Encore	Body	Parking Assist Control Module	V	V																	V	V																																		
J	2015	Encore	Body	Frontview Camera Module	V	V																	V	V																																		
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V												V														
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V												V	V														
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																				
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V														
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit	V	V																	V	V										V	V	V	V	V	V																				
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V														
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit	V	V																	V	V										V	V	V	V	V	V																				
J	2016	Encore	Powertrain	Chassis Control Module	V	V																	V	V							V		V																										
J	2016	Encore	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V						
J	2016	Encore	Chassis	Power Steering Control Module	V	V																		V																																		
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module	V																			V																																		
J	2016	Encore	Body	Body Control Module	V	V																	V	V																																		
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
J	2016	Encore	Body	Passenger Presence Module	V	V																		V																																		
J	2016	Encore	Body	Instrument Cluster	V	V																	V	V																																		
J	2016	Encore	Body	Radio	V	V																	V	V																																		
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7	V	V																	V	V																																		
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																		
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)	V	V																	V	V																																		
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)	V	V																	V	V																																		
J	2016	Encore	Body	Seat Memory Control Module	V																																																				
J	2016	Encore	Body	Front Seat Heating Control Module	V	V																	V	V																																		
J	2016	Encore	Body	Left Side Object Detection Control Module	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2016	Encore	Body	Parking Assist Control Module	V	V																		V	V																																			
J	2016	Encore	Body	Frontview Camera Module	V	V																		V	V																																			
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V		V														
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V								V													
R	2014	Enclave	Powertrain	Chassis Control Module	V	V																		V	V							V		V																									
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
R	2014	Enclave	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
R	2014	Enclave	Body	Body Control Module	V	V																		V	V																																		
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
R	2014	Enclave	Body	Passenger Presence Module	V	V																			V																																		
R	2014	Enclave	Body	Instrument Cluster	V	V																		V	V																																		
R	2014	Enclave	Body	Headlamp Control Module	V																				V																																		
R	2014	Enclave	Body	Radio	V	V																		V	V																																		
R	2014	Enclave	Body	Rear Audio Control Module	V	V																			V																																		
R	2014	Enclave	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
R	2014	Enclave	Body	Personal Audio Link Control Module	V																				V																																		
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
R	2014	Enclave	Body	HVAC Control Module	V	V																		V	V																																		
R	2014	Enclave	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V											
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
R	2014	Enclave	Body	Liftgate Control Module	V	V																			V																						V											
R	2014	Enclave	Body	Seat Memory Control Module	V	V																		V	V																																		
R	2014	Enclave	Body	Front Seat Heating Control Module	V	V																			V																																		
R	2014	Enclave	Body	Right Side Object Detection Control Module	V																			V	V																																		
R	2014	Enclave	Body	Left Side Object Detection Control Module	V																			V	V																																		
R	2014	Enclave	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
R	2014	Enclave	Body	Parking Assist Control Module	V																			V	V																																		
R	2014	Enclave	Body	Frontview Camera Module	V	V																		V	V																																		
R	2014	Enclave	Body	Theft Deterrent Module	V	V																			V																																		
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V		V														
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V								V													
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
R	2015	Enclave	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
R	2015	Enclave	Body	Body Control Module	V	V																		V	V																																		
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
R	2015	Enclave	Body	Passenger Presence Module	V	V																			V																																		
R	2015	Enclave	Body	Instrument Cluster	V	V																		V	V																																		
R	2015	Enclave	Body	Head-Up Display Module	V	V																		V	V																																		
R	2015	Enclave	Body	Headlamp Control Module	V																				V																																		
R	2015	Enclave	Body	Radio	V	V																		V	V																																		
R	2015	Enclave	Body	Rear Audio Control Module	V	V																			V																																		
R	2015	Enclave	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
R	2015	Enclave	Body	Personal Audio Link Control Module	V																				V																																		
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
R	2015	Enclave	Body	HVAC Control Module	V	V																		V	V																																		
R	2015	Enclave	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V											
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
R	2015	Enclave	Body	Liftgate Control Module	V	V																			V																						V											
R	2015	Enclave	Body	Seat Memory Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2015	Enclave	Body	Front Seat Heating Control Module	V	V																			V																																		
R	2015	Enclave	Body	Right Side Object Detection Control Module	V																			V	V																																		
R	2015	Enclave	Body	Left Side Object Detection Control Module	V																			V	V																																		
R	2015	Enclave	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
R	2015	Enclave	Body	Parking Assist Control Module	V																			V	V																																		
R	2015	Enclave	Body	Frontview Camera Module	V	V																		V	V																																		
R	2015	Enclave	Body	Theft Deterrent Module	V	V																			V																																		
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V		V													
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V								V													
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
R	2016	Enclave	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
R	2016	Enclave	Body	Body Control Module	V	V																		V	V																																		
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
R	2016	Enclave	Body	Passenger Presence Module	V	V																			V																																		
R	2016	Enclave	Body	Instrument Cluster	V	V																		V	V																																		
R	2016	Enclave	Body	Head-Up Display Module	V	V																		V	V																																		
R	2016	Enclave	Body	Headlamp Control Module	V																				V																																		
R	2016	Enclave	Body	Radio	V	V																		V	V																																		
R	2016	Enclave	Body	Rear Audio Control Module	V	V																			V																																		
R	2016	Enclave	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
R	2016	Enclave	Body	Personal Audio Link Control Module	V																				V																																		
R	2016	Enclave	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
R	2016	Enclave	Body	HVAC Control Module	V	V																		V	V																																		
R	2016	Enclave	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V											
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
R	2016	Enclave	Body	Liftgate Control Module	V	V																			V																						V											
R	2016	Enclave	Body	Seat Memory Control Module	V	V																		V	V																																		
R	2016	Enclave	Body	Front Seat Heating Control Module	V	V																			V																																		
R	2016	Enclave	Body	Right Side Object Detection Control Module	V																			V	V																																		
R	2016	Enclave	Body	Left Side Object Detection Control Module	V																			V	V																																		
R	2016	Enclave	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
R	2016	Enclave	Body	Parking Assist Control Module	V																			V	V																																		
R	2016	Enclave	Body	Frontview Camera Module	V	V																		V	V																																		
R	2016	Enclave	Body	Theft Deterrent Module	V	V																			V																																		
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V		V													
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V								V													
V	2014	Enclave	Powertrain	Chassis Control Module	V	V																		V	V							V		V																									
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
V	2014	Enclave	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
V	2014	Enclave	Body	Body Control Module	V	V																		V	V																																		
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
V	2014	Enclave	Body	Passenger Presence Module	V	V																			V																																		
V	2014	Enclave	Body	Instrument Cluster	V	V																		V	V																																		
V	2014	Enclave	Body	Headlamp Control Module	V																				V																																		
V	2014	Enclave	Body	Radio	V	V																		V	V																																		
V	2014	Enclave	Body	Rear Audio Control Module	V	V																			V																																		
V	2014	Enclave	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
V	2014	Enclave	Body	Personal Audio Link Control Module	V																				V																																		
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
V	2014	Enclave	Body	HVAC Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
V	2014	Enclave	Body	Driver Door Switch Panel Control Module	V	V																		V	V																					V													
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
V	2014	Enclave	Body	Liftgate Control Module	V	V																			V																					V												
V	2014	Enclave	Body	Seat Memory Control Module	V	V																		V	V																																		
V	2014	Enclave	Body	Front Seat Heating Control Module	V	V																			V																																		
V	2014	Enclave	Body	Right Side Object Detection Control Module	V																			V	V																																		
V	2014	Enclave	Body	Left Side Object Detection Control Module	V																			V	V																																		
V	2014	Enclave	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
V	2014	Enclave	Body	Parking Assist Control Module	V																			V	V																																		
V	2014	Enclave	Body	Frontview Camera Module	V	V																		V	V																																		
V	2014	Enclave	Body	Theft Deterrent Module	V	V																			V																																		
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V												
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V									V											
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
V	2015	Enclave	Chassis	Electronic Brake Control Module	V	V																		V	V													V											V	V	V	V	V	V						V
V	2015	Enclave	Body	Body Control Module	V	V																		V	V																																		
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
V	2015	Enclave	Body	Passenger Presence Module	V	V																			V																																		
V	2015	Enclave	Body	Instrument Cluster	V	V																		V	V																																		
V	2015	Enclave	Body	Head-Up Display Module	V	V																		V	V																																		
V	2015	Enclave	Body	Headlamp Control Module	V																				V																																		
V	2015	Enclave	Body	Radio	V	V																		V	V																																		
V	2015	Enclave	Body	Rear Audio Control Module	V	V																			V																																		
V	2015	Enclave	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
V	2015	Enclave	Body	Personal Audio Link Control Module	V																				V																																		
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
V	2015	Enclave	Body	HVAC Control Module	V	V																		V	V																																		
V	2015	Enclave	Body	Driver Door Switch Panel Control Module	V	V																		V	V																					V												
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
V	2015	Enclave	Body	Liftgate Control Module	V	V																			V																					V												
V	2015	Enclave	Body	Seat Memory Control Module	V	V																		V	V																																		
V	2015	Enclave	Body	Front Seat Heating Control Module	V	V																			V																																		
V	2015	Enclave	Body	Right Side Object Detection Control Module	V																			V	V																																		
V	2015	Enclave	Body	Left Side Object Detection Control Module	V																			V	V																																		
V	2015	Enclave	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
V	2015	Enclave	Body	Parking Assist Control Module	V																			V	V																																		
V	2015	Enclave	Body	Frontview Camera Module	V	V																		V	V																																		
V	2015	Enclave	Body	Theft Deterrent Module	V	V																			V																																		
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V												
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V									V											
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
V	2016	Enclave	Chassis	Electronic Brake Control Module	V	V																		V	V													V											V	V	V	V	V	V						V
V	2016	Enclave	Body	Body Control Module	V	V																		V	V																																		
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
V	2016	Enclave	Body	Passenger Presence Module	V	V																			V																																		
V	2016	Enclave	Body	Instrument Cluster	V	V																		V	V																																		
V	2016	Enclave	Body	Head-Up Display Module	V	V																		V	V																																		
V	2016	Enclave	Body	Headlamp Control Module	V																				V																																		
V	2016	Enclave	Body	Radio	V	V																		V	V																																		
V	2016	Enclave	Body	Rear Audio Control Module	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
V	2016	Enclave	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
V	2016	Enclave	Body	Personal Audio Link Control Module	V																				V																																			
V	2016	Enclave	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
V	2016	Enclave	Body	HVAC Control Module	V	V																		V	V																																			
V	2016	Enclave	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V												
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																			
V	2016	Enclave	Body	Liftgate Control Module	V	V																			V																						V												
V	2016	Enclave	Body	Seat Memory Control Module	V	V																		V	V																																			
V	2016	Enclave	Body	Front Seat Heating Control Module	V	V																			V																																			
V	2016	Enclave	Body	Right Side Object Detection Control Module	V																			V	V																																			
V	2016	Enclave	Body	Left Side Object Detection Control Module	V																			V	V																																			
V	2016	Enclave	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
V	2016	Enclave	Body	Parking Assist Control Module	V																			V	V																																			
V	2016	Enclave	Body	Frontview Camera Module	V	V																		V	V																																			
V	2016	Enclave	Body	Theft Deterrent Module	V	V																			V																																			
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V													V												
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V												V	V												
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module	V																			V	V				V	V	V	V	V												V												
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V												
X	2016	Envision	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V				V		
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
X	2016	Envision	Chassis	Power Steering Control Module	V	V																			V																																			
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
X	2016	Envision	Body	Passenger Presence Module	V	V																			V																																			
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																		V	V																																			
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)	V	V																		V	V																																			
X	2016	Envision	Body	Radio Controls	V																				V																																			
X	2016	Envision	Body	HVAC Controls	V																			V	V																																			
X	2016	Envision	Body	Video Processing Control Module	V	V																		V	V																																			
X	2016	Envision	Body	Headlamp Control Module	V	V																		V	V																						V												
X	2016	Envision	Body	Radio	V	V																		V	V																																			
X	2016	Envision	Body	Amplifier	V	V																			V																																			
X	2016	Envision	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																			
X	2016	Envision	Body	Liftgate Control Module	V	V																		V	V																						V												
X	2016	Envision	Body	Seat Memory Control Module - Driver	V																																																						
X	2016	Envision	Body	Keyless Entry Control Module	V	V																		V	V																																			
X	2016	Envision	Body	Right Side Object Detection Control Module	V																			V	V																																			
X	2016	Envision	Body	Left Side Object Detection Control Module	V																			V	V																																			
X	2016	Envision	Body	Parking Assist Control Module	V	V																		V	V																																			
X	2016	Envision	Body	Frontview Camera Module	V	V																		V	V																																			
X	2016	Envision	Body	Frontview Camera Module	V	V																			V																																			
X	2016	Envision	Body	Steering Column Lock Control Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
X	2016	Envision	Body	Power Supply Transformer	V																				V																																				
X	2016	Envision	Body	Long Range Radar Sensor Module	V	V																			V																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																										
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2013	Encore	Powertrain	Fuel Pump Control Module																																																										
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module																																																										
J	2013	Encore	Chassis	Electronic Brake Control Module					V																																																					
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Encore	Chassis	Power Steering Control Module																																																										
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
J	2013	Encore	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V							
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
J	2013	Encore	Body	Passenger Presence Module																																V																										
J	2013	Encore	Body	Instrument Cluster																					V												V																								
J	2013	Encore	Body	Radio																																																										
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																				
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)																														V												V	V	V	V	V								
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V								
J	2013	Encore	Body	Seat Memory Control Module																																																									
J	2013	Encore	Body	Front Seat Heating Control Module																																						V	V																			
J	2013	Encore	Body	Parking Assist Control Module																																	V																								
J	2013	Encore	Body	Frontview Camera Module																																																										
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit																																																										
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2014	Encore	Powertrain	Chassis Control Module																																																										
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module																																																										
J	2014	Encore	Chassis	Electronic Brake Control Module					V																																																					
J	2014	Encore	Chassis	Power Steering Control Module																																																										
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
J	2014	Encore	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V							
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
J	2014	Encore	Body	Passenger Presence Module																																V																										
J	2014	Encore	Body	Instrument Cluster																																	V																								
J	2014	Encore	Body	Radio Other																																																										
J	2014	Encore	Body	Radio (UF7)																																																										
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																				
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)																														V												V	V	V	V	V								
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V								
J	2014	Encore	Body	Seat Memory Control Module																																																										
J	2014	Encore	Body	Front Seat Heating Control Module																																						V	V																			
J	2014	Encore	Body	Left Side Object Detection Control Module																																																										
J	2014	Encore	Body	Parking Assist Control Module																																	V																								
J	2014	Encore	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																										
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2015	Encore	Powertrain	Chassis Control Module																																																										
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Encore	Chassis	Electronic Brake Control Module					V																																																					
J	2015	Encore	Chassis	Power Steering Control Module																																																										
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
J	2015	Encore	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																											V						
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
J	2015	Encore	Body	Passenger Presence Module																																V																											
J	2015	Encore	Body	Instrument Cluster																																	V																									
J	2015	Encore	Body	Radio Other																																																									
J	2015	Encore	Body	Radio (UF7)																																																									
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)																														V												V	V	V	V									
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V									
J	2015	Encore	Body	Seat Memory Control Module																																																									
J	2015	Encore	Body	Front Seat Heating Control Module																																					V	V																				
J	2015	Encore	Body	Left Side Object Detection Control Module																																																										
J	2015	Encore	Body	Parking Assist Control Module																																V																											
J	2015	Encore	Body	Frontview Camera Module																																																										
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																				V																																						
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																										
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2016	Encore	Powertrain	Chassis Control Module																																																										
J	2016	Encore	Chassis	Electronic Brake Control Module					V																																																					
J	2016	Encore	Chassis	Power Steering Control Module																																																										
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
J	2016	Encore	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																											V						
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
J	2016	Encore	Body	Passenger Presence Module																																V																											
J	2016	Encore	Body	Instrument Cluster																																	V																									
J	2016	Encore	Body	Radio																																																									
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)																														V												V	V	V	V									
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V									
J	2016	Encore	Body	Seat Memory Control Module																																																									
J	2016	Encore	Body	Front Seat Heating Control Module																																					V	V																				
J	2016	Encore	Body	Left Side Object Detection Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2016	Encore	Body	Parking Assist Control Module																																	V																							
J	2016	Encore	Body	Frontview Camera Module																																																							
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																			
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																							
R	2014	Enclave	Powertrain	Chassis Control Module																																																							
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																						
R	2014	Enclave	Chassis	Electronic Brake Control Module					V																																																	
R	2014	Enclave	Body	Body Control Module						V	V	V						V					V	V																																			
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																								
R	2014	Enclave	Body	Passenger Presence Module																										V						V																							
R	2014	Enclave	Body	Instrument Cluster																																																						
R	2014	Enclave	Body	Headlamp Control Module																																																						
R	2014	Enclave	Body	Radio																																																						
R	2014	Enclave	Body	Rear Audio Control Module																																																						
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																																						
R	2014	Enclave	Body	Personal Audio Link Control Module																																																						
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																				
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																				
R	2014	Enclave	Body	HVAC Control Module																																										V	V			V								
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																	V																																						
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																						
R	2014	Enclave	Body	Liftgate Control Module																																																						
R	2014	Enclave	Body	Seat Memory Control Module																																					V	V																
R	2014	Enclave	Body	Front Seat Heating Control Module																																					V	V																
R	2014	Enclave	Body	Right Side Object Detection Control Module																																																						
R	2014	Enclave	Body	Left Side Object Detection Control Module																																																						
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																																						
R	2014	Enclave	Body	Parking Assist Control Module																																V																							
R	2014	Enclave	Body	Frontview Camera Module																																																						
R	2014	Enclave	Body	Theft Deterrent Module										V																																												
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																			
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																						
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																						
R	2015	Enclave	Chassis	Electronic Brake Control Module					V																																																	
R	2015	Enclave	Body	Body Control Module						V	V	V						V					V	V																																			
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																								
R	2015	Enclave	Body	Passenger Presence Module																										V						V																							
R	2015	Enclave	Body	Instrument Cluster																																																						
R	2015	Enclave	Body	Head-Up Display Module																																																						
R	2015	Enclave	Body	Headlamp Control Module																																																						
R	2015	Enclave	Body	Radio																																																						
R	2015	Enclave	Body	Rear Audio Control Module																																																						
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																																						
R	2015	Enclave	Body	Personal Audio Link Control Module																																																						
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																				
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																				
R	2015	Enclave	Body	HVAC Control Module																																										V	V			V								
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																	V																																						
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																						
R	2015	Enclave	Body	Liftgate Control Module																																																						
R	2015	Enclave	Body	Seat Memory Control Module																																					V	V																

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2015	Enclave	Body	Front Seat Heating Control Module																																						V	V																		
R	2015	Enclave	Body	Right Side Object Detection Control Module																																																								
R	2015	Enclave	Body	Left Side Object Detection Control Module																																																								
R	2015	Enclave	Body	Remote Control Door Lock Receiver																																																								
R	2015	Enclave	Body	Parking Assist Control Module																																V																									
R	2015	Enclave	Body	Frontview Camera Module																																																								
R	2015	Enclave	Body	Theft Deterrent Module										V																																														
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																				
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																								
R	2016	Enclave	Chassis	Electronic Brake Control Module					V																																																			
R	2016	Enclave	Body	Body Control Module						V	V	V						V					V	V																																				
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
R	2016	Enclave	Body	Passenger Presence Module																										V						V																								
R	2016	Enclave	Body	Instrument Cluster																																																							
R	2016	Enclave	Body	Head-Up Display Module																																																							
R	2016	Enclave	Body	Headlamp Control Module																																																							
R	2016	Enclave	Body	Radio																																																							
R	2016	Enclave	Body	Rear Audio Control Module																																																							
R	2016	Enclave	Body	Digital Radio Receiver Control Module																																																							
R	2016	Enclave	Body	Personal Audio Link Control Module																																																							
R	2016	Enclave	Body	Telematics Communication Interface Control Module																																	V	V	V																					
R	2016	Enclave	Body	HVAC Control Module																																										V	V			V									
R	2016	Enclave	Body	Driver Door Switch Panel Control Module																	V																																						
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																							
R	2016	Enclave	Body	Liftgate Control Module																																																							
R	2016	Enclave	Body	Seat Memory Control Module																																						V	V																	
R	2016	Enclave	Body	Front Seat Heating Control Module																																						V	V																	
R	2016	Enclave	Body	Right Side Object Detection Control Module																																																							
R	2016	Enclave	Body	Left Side Object Detection Control Module																																																							
R	2016	Enclave	Body	Remote Control Door Lock Receiver																																																							
R	2016	Enclave	Body	Parking Assist Control Module																																V																							
R	2016	Enclave	Body	Frontview Camera Module																																																							
R	2016	Enclave	Body	Theft Deterrent Module										V																																													
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																				
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
V	2014	Enclave	Powertrain	Chassis Control Module																																																								
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																								
V	2014	Enclave	Chassis	Electronic Brake Control Module					V																																																			
V	2014	Enclave	Body	Body Control Module						V	V	V						V					V	V																																				
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
V	2014	Enclave	Body	Passenger Presence Module																										V						V																								
V	2014	Enclave	Body	Instrument Cluster																																																							
V	2014	Enclave	Body	Headlamp Control Module																																																							
V	2014	Enclave	Body	Radio																																																							
V	2014	Enclave	Body	Rear Audio Control Module																																																							
V	2014	Enclave	Body	Digital Radio Receiver Control Module																																																							
V	2014	Enclave	Body	Personal Audio Link Control Module																																																							
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																			
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
V	2014	Enclave	Body	HVAC Control Module																																										V	V			V									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																	V																																								
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																									
V	2014	Enclave	Body	Liftgate Control Module																																																									
V	2014	Enclave	Body	Seat Memory Control Module																																					V	V																			
V	2014	Enclave	Body	Front Seat Heating Control Module																																					V	V																			
V	2014	Enclave	Body	Right Side Object Detection Control Module																																																									
V	2014	Enclave	Body	Left Side Object Detection Control Module																																																									
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																																									
V	2014	Enclave	Body	Parking Assist Control Module																																V																										
V	2014	Enclave	Body	Frontview Camera Module																																																									
V	2014	Enclave	Body	Theft Deterrent Module										V																																															
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																					
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																									
V	2015	Enclave	Chassis	Electronic Brake Control Module					V																																																				
V	2015	Enclave	Body	Body Control Module						V	V	V						V					V	V																																					
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
V	2015	Enclave	Body	Passenger Presence Module																										V						V																										
V	2015	Enclave	Body	Instrument Cluster																																																									
V	2015	Enclave	Body	Head-Up Display Module																																																									
V	2015	Enclave	Body	Headlamp Control Module																																																									
V	2015	Enclave	Body	Radio																																																									
V	2015	Enclave	Body	Rear Audio Control Module																																																									
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																																									
V	2015	Enclave	Body	Personal Audio Link Control Module																																																									
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																					
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
V	2015	Enclave	Body	HVAC Control Module																																										V	V			V										
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																	V																																								
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																									
V	2015	Enclave	Body	Liftgate Control Module																																																									
V	2015	Enclave	Body	Seat Memory Control Module																																					V	V																			
V	2015	Enclave	Body	Front Seat Heating Control Module																																					V	V																			
V	2015	Enclave	Body	Right Side Object Detection Control Module																																																									
V	2015	Enclave	Body	Left Side Object Detection Control Module																																																									
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																																									
V	2015	Enclave	Body	Parking Assist Control Module																																V																										
V	2015	Enclave	Body	Frontview Camera Module																																																									
V	2015	Enclave	Body	Theft Deterrent Module										V																																															
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																					
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																									
V	2016	Enclave	Chassis	Electronic Brake Control Module					V																																																				
V	2016	Enclave	Body	Body Control Module						V	V	V						V					V	V																																					
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
V	2016	Enclave	Body	Passenger Presence Module																										V						V																										
V	2016	Enclave	Body	Instrument Cluster																																																									
V	2016	Enclave	Body	Head-Up Display Module																																																									
V	2016	Enclave	Body	Headlamp Control Module																																																									
V	2016	Enclave	Body	Radio																																																									
V	2016	Enclave	Body	Rear Audio Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
V	2016	Enclave	Body	Digital Radio Receiver Control Module																																																									
V	2016	Enclave	Body	Personal Audio Link Control Module																																																										
V	2016	Enclave	Body	Telematics Communication Interface Control Module																																	V	V	V																						
V	2016	Enclave	Body	HVAC Control Module																																										V	V			V									
V	2016	Enclave	Body	Driver Door Switch Panel Control Module																	V																					V	V																	
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																								
V	2016	Enclave	Body	Liftgate Control Module																																																								
V	2016	Enclave	Body	Seat Memory Control Module																																					V	V																	
V	2016	Enclave	Body	Front Seat Heating Control Module																																					V	V																	
V	2016	Enclave	Body	Right Side Object Detection Control Module																																																								
V	2016	Enclave	Body	Left Side Object Detection Control Module																																																								
V	2016	Enclave	Body	Remote Control Door Lock Receiver																																																								
V	2016	Enclave	Body	Parking Assist Control Module																																V																								
V	2016	Enclave	Body	Frontview Camera Module																																																								
V	2016	Enclave	Body	Theft Deterrent Module										V																																														
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																				V																																				
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																								
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module																				V																																				
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module																																																								
X	2016	Envision	Chassis	Electronic Brake Control Module					V																																																			
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module																																																								
X	2016	Envision	Chassis	Power Steering Control Module	V	V	V																																																					
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V		V	V	V		V	V	V	V	V	V	V	V																								V							
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V		V	V	V		V	V	V	V	V	V	V	V																								V							
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
X	2016	Envision	Body	Passenger Presence Module																																V																								
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																	V																							
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																	V																							
X	2016	Envision	Body	Radio Controls																																																								
X	2016	Envision	Body	HVAC Controls																																																								
X	2016	Envision	Body	Video Processing Control Module																																																								
X	2016	Envision	Body	Headlamp Control Module																																																								
X	2016	Envision	Body	Radio																																																								
X	2016	Envision	Body	Amplifier																																																								
X	2016	Envision	Body	Human Machine Interface Control Module																																																								
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																						
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																						
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)																														V													V	V		V									
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)																														V													V	V		V									
X	2016	Envision	Body	Liftgate Control Module																																																								
X	2016	Envision	Body	Seat Memory Control Module - Driver																																																								
X	2016	Envision	Body	Keyless Entry Control Module																																																								
X	2016	Envision	Body	Right Side Object Detection Control Module																																																								
X	2016	Envision	Body	Left Side Object Detection Control Module																																																								
X	2016	Envision	Body	Parking Assist Control Module																																																								
X	2016	Envision	Body	Frontview Camera Module																																																								
X	2016	Envision	Body	Frontview Camera Module																																																								
X	2016	Envision	Body	Steering Column Lock Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
X	2016	Envision	Body	Power Supply Transformer																																																																
X	2016	Envision	Body	Long Range Radar Sensor Module																																																																

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2016	Encore	Body	Parking Assist Control Module																																						V	V	V																
J	2016	Encore	Body	Frontview Camera Module																											V	V																											
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module							V																																																
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																							
R	2014	Enclave	Powertrain	Chassis Control Module																																																						
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																						
R	2014	Enclave	Chassis	Electronic Brake Control Module											V	V	V	V	V																																							
R	2014	Enclave	Body	Body Control Module		V															V																				V																		
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
R	2014	Enclave	Body	Passenger Presence Module																																																					
R	2014	Enclave	Body	Instrument Cluster																																																					
R	2014	Enclave	Body	Headlamp Control Module																																																					
R	2014	Enclave	Body	Radio																																																					
R	2014	Enclave	Body	Rear Audio Control Module																																																					
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																																					
R	2014	Enclave	Body	Personal Audio Link Control Module																																																					
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																					
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																					
R	2014	Enclave	Body	HVAC Control Module																																																					
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																					
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																					
R	2014	Enclave	Body	Liftgate Control Module																																																					
R	2014	Enclave	Body	Seat Memory Control Module																																																					
R	2014	Enclave	Body	Front Seat Heating Control Module																																																					
R	2014	Enclave	Body	Right Side Object Detection Control Module																																																					
R	2014	Enclave	Body	Left Side Object Detection Control Module																																																					
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																																					
R	2014	Enclave	Body	Parking Assist Control Module																																																					
R	2014	Enclave	Body	Frontview Camera Module																											V	V																											
R	2014	Enclave	Body	Theft Deterrent Module																																																					
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																					
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																					
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																					
R	2015	Enclave	Chassis	Electronic Brake Control Module											V	V	V	V	V																																							
R	2015	Enclave	Body	Body Control Module		V															V																				V																		
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																					
R	2015	Enclave	Body	Passenger Presence Module																																																					
R	2015	Enclave	Body	Instrument Cluster																																																					
R	2015	Enclave	Body	Head-Up Display Module																																																					
R	2015	Enclave	Body	Headlamp Control Module																																																					
R	2015	Enclave	Body	Radio																																																					
R	2015	Enclave	Body	Rear Audio Control Module																																																					
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																																					
R	2015	Enclave	Body	Personal Audio Link Control Module																																																					
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																					
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																					
R	2015	Enclave	Body	HVAC Control Module																																																					
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																					
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																					
R	2015	Enclave	Body	Liftgate Control Module																																																					
R	2015	Enclave	Body	Seat Memory Control Module																																																					

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																														
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																													
V	2014	Enclave	Body	Liftgate Control Module																																																													
V	2014	Enclave	Body	Seat Memory Control Module																																																													
V	2014	Enclave	Body	Front Seat Heating Control Module																																																													
V	2014	Enclave	Body	Right Side Object Detection Control Module																																																													
V	2014	Enclave	Body	Left Side Object Detection Control Module																																																													
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																																													
V	2014	Enclave	Body	Parking Assist Control Module																																																													
V	2014	Enclave	Body	Frontview Camera Module																											V	V																																	
V	2014	Enclave	Body	Theft Deterrent Module																																																													
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																														
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																														
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																														
V	2015	Enclave	Chassis	Electronic Brake Control Module											V	V	V	V	V																																														
V	2015	Enclave	Body	Body Control Module		V															V																						V																					
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
V	2015	Enclave	Body	Passenger Presence Module																																																														
V	2015	Enclave	Body	Instrument Cluster																																																														
V	2015	Enclave	Body	Head-Up Display Module																																																														
V	2015	Enclave	Body	Headlamp Control Module																																																														
V	2015	Enclave	Body	Radio																																																														
V	2015	Enclave	Body	Rear Audio Control Module																																																														
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																																														
V	2015	Enclave	Body	Personal Audio Link Control Module																																																														
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																														
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																														
V	2015	Enclave	Body	HVAC Control Module																																																														
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																														
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																														
V	2015	Enclave	Body	Liftgate Control Module																																																														
V	2015	Enclave	Body	Seat Memory Control Module																																																														
V	2015	Enclave	Body	Front Seat Heating Control Module																																																														
V	2015	Enclave	Body	Right Side Object Detection Control Module																																																														
V	2015	Enclave	Body	Left Side Object Detection Control Module																																																														
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																																														
V	2015	Enclave	Body	Parking Assist Control Module																																																														
V	2015	Enclave	Body	Frontview Camera Module																											V	V																																	
V	2015	Enclave	Body	Theft Deterrent Module																																																														
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																														
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																														
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																														
V	2016	Enclave	Chassis	Electronic Brake Control Module											V	V	V	V	V																																														
V	2016	Enclave	Body	Body Control Module		V															V																						V																					
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
V	2016	Enclave	Body	Passenger Presence Module																																																														
V	2016	Enclave	Body	Instrument Cluster																																																														
V	2016	Enclave	Body	Head-Up Display Module																																																														
V	2016	Enclave	Body	Headlamp Control Module																																																														
V	2016	Enclave	Body	Radio																																																														
V	2016	Enclave	Body	Rear Audio Control Module																																																														

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																										
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2013	Encore	Powertrain	Fuel Pump Control Module																																																										
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module																																																										
J	2013	Encore	Chassis	Electronic Brake Control Module																																																										
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Encore	Chassis	Power Steering Control Module																																																										
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Encore	Body	Body Control Module																																																										
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Encore	Body	Passenger Presence Module																																																										
J	2013	Encore	Body	Instrument Cluster																																																										
J	2013	Encore	Body	Radio																																																										
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																										
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)																																																										
J	2013	Encore	Body	Seat Memory Control Module																																																										
J	2013	Encore	Body	Front Seat Heating Control Module																																																										
J	2013	Encore	Body	Parking Assist Control Module																																																										
J	2013	Encore	Body	Frontview Camera Module																																																										
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit																																																										
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2014	Encore	Powertrain	Chassis Control Module																																																										
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module						V																																																			
J	2014	Encore	Chassis	Electronic Brake Control Module																																																										
J	2014	Encore	Chassis	Power Steering Control Module																																																										
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Encore	Body	Body Control Module																																																										
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Encore	Body	Passenger Presence Module																																																										
J	2014	Encore	Body	Instrument Cluster																																																										
J	2014	Encore	Body	Radio Other																																																										
J	2014	Encore	Body	Radio (UF7)																																																										
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																										
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)																																																										
J	2014	Encore	Body	Seat Memory Control Module																																																										
J	2014	Encore	Body	Front Seat Heating Control Module																																																										
J	2014	Encore	Body	Left Side Object Detection Control Module																																																										
J	2014	Encore	Body	Parking Assist Control Module																																																										
J	2014	Encore	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																										
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2015	Encore	Powertrain	Chassis Control Module																																																										
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module						V																																																			
J	2015	Encore	Chassis	Electronic Brake Control Module																																																										
J	2015	Encore	Chassis	Power Steering Control Module																																																										
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Encore	Body	Body Control Module																																																										
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Encore	Body	Passenger Presence Module																																																										
J	2015	Encore	Body	Instrument Cluster																																																										
J	2015	Encore	Body	Radio Other																																																										
J	2015	Encore	Body	Radio (UF7)																																																										
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																										
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)																																																										
J	2015	Encore	Body	Seat Memory Control Module																																																										
J	2015	Encore	Body	Front Seat Heating Control Module																																																										
J	2015	Encore	Body	Left Side Object Detection Control Module																																																										
J	2015	Encore	Body	Parking Assist Control Module																																																										
J	2015	Encore	Body	Frontview Camera Module																																																										
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																										
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2016	Encore	Powertrain	Chassis Control Module																																																										
J	2016	Encore	Chassis	Electronic Brake Control Module																																																										
J	2016	Encore	Chassis	Power Steering Control Module																																																										
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Encore	Body	Body Control Module																																																										
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Encore	Body	Passenger Presence Module																																																										
J	2016	Encore	Body	Instrument Cluster																																																										
J	2016	Encore	Body	Radio																																																										
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																										
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)																																																										
J	2016	Encore	Body	Seat Memory Control Module																																																										
J	2016	Encore	Body	Front Seat Heating Control Module																																																										
J	2016	Encore	Body	Left Side Object Detection Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2016	Encore	Body	Parking Assist Control Module																																																								
J	2016	Encore	Body	Frontview Camera Module																																																								
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2014	Enclave	Powertrain	Chassis Control Module																																																								
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																								
R	2014	Enclave	Chassis	Electronic Brake Control Module																																																								
R	2014	Enclave	Body	Body Control Module																																																								
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2014	Enclave	Body	Passenger Presence Module																																																								
R	2014	Enclave	Body	Instrument Cluster																																																								
R	2014	Enclave	Body	Headlamp Control Module																																																								
R	2014	Enclave	Body	Radio																																																								
R	2014	Enclave	Body	Rear Audio Control Module																																																								
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																																								
R	2014	Enclave	Body	Personal Audio Link Control Module																																																								
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2014	Enclave	Body	HVAC Control Module																																																								
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																								
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																								
R	2014	Enclave	Body	Liftgate Control Module																																																								
R	2014	Enclave	Body	Seat Memory Control Module																																																								
R	2014	Enclave	Body	Front Seat Heating Control Module																																																								
R	2014	Enclave	Body	Right Side Object Detection Control Module																																																								
R	2014	Enclave	Body	Left Side Object Detection Control Module																																																								
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																																								
R	2014	Enclave	Body	Parking Assist Control Module																																																								
R	2014	Enclave	Body	Frontview Camera Module																																																								
R	2014	Enclave	Body	Theft Deterrent Module																																																								
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																								
R	2015	Enclave	Chassis	Electronic Brake Control Module																																																								
R	2015	Enclave	Body	Body Control Module																																																								
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2015	Enclave	Body	Passenger Presence Module																																																								
R	2015	Enclave	Body	Instrument Cluster																																																								
R	2015	Enclave	Body	Head-Up Display Module																																																								
R	2015	Enclave	Body	Headlamp Control Module																																																								
R	2015	Enclave	Body	Radio																																																								
R	2015	Enclave	Body	Rear Audio Control Module																																																								
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																																								
R	2015	Enclave	Body	Personal Audio Link Control Module																																																								
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2015	Enclave	Body	HVAC Control Module																																																								
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																								
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																								
R	2015	Enclave	Body	Liftgate Control Module																																																								
R	2015	Enclave	Body	Seat Memory Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2015	Enclave	Body	Front Seat Heating Control Module																																																									
R	2015	Enclave	Body	Right Side Object Detection Control Module																																																										
R	2015	Enclave	Body	Left Side Object Detection Control Module																																																										
R	2015	Enclave	Body	Remote Control Door Lock Receiver																																																										
R	2015	Enclave	Body	Parking Assist Control Module																																																										
R	2015	Enclave	Body	Frontview Camera Module																																																										
R	2015	Enclave	Body	Theft Deterrent Module																																																										
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
R	2016	Enclave	Chassis	Electronic Brake Control Module																																																										
R	2016	Enclave	Body	Body Control Module																																																										
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Enclave	Body	Passenger Presence Module																																																										
R	2016	Enclave	Body	Instrument Cluster																																																										
R	2016	Enclave	Body	Head-Up Display Module																																																										
R	2016	Enclave	Body	Headlamp Control Module																																																										
R	2016	Enclave	Body	Radio																																																										
R	2016	Enclave	Body	Rear Audio Control Module																																																										
R	2016	Enclave	Body	Digital Radio Receiver Control Module																																																										
R	2016	Enclave	Body	Personal Audio Link Control Module																																																										
R	2016	Enclave	Body	Telematics Communication Interface Control Module																																																										
R	2016	Enclave	Body	HVAC Control Module																																																										
R	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Enclave	Body	Liftgate Control Module																																																										
R	2016	Enclave	Body	Seat Memory Control Module																																																										
R	2016	Enclave	Body	Front Seat Heating Control Module																																																										
R	2016	Enclave	Body	Right Side Object Detection Control Module																																																										
R	2016	Enclave	Body	Left Side Object Detection Control Module																																																										
R	2016	Enclave	Body	Remote Control Door Lock Receiver																																																										
R	2016	Enclave	Body	Parking Assist Control Module																																																										
R	2016	Enclave	Body	Frontview Camera Module																																																										
R	2016	Enclave	Body	Theft Deterrent Module																																																										
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2014	Enclave	Powertrain	Chassis Control Module																																																										
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2014	Enclave	Chassis	Electronic Brake Control Module																																																										
V	2014	Enclave	Body	Body Control Module																																																										
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2014	Enclave	Body	Passenger Presence Module																																																										
V	2014	Enclave	Body	Instrument Cluster																																																										
V	2014	Enclave	Body	Headlamp Control Module																																																										
V	2014	Enclave	Body	Radio																																																										
V	2014	Enclave	Body	Rear Audio Control Module																																																										
V	2014	Enclave	Body	Digital Radio Receiver Control Module																																																										
V	2014	Enclave	Body	Personal Audio Link Control Module																																																										
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2014	Enclave	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																									
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2014	Enclave	Body	Liftgate Control Module																																																										
V	2014	Enclave	Body	Seat Memory Control Module																																																										
V	2014	Enclave	Body	Front Seat Heating Control Module																																																										
V	2014	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2014	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2014	Enclave	Body	Parking Assist Control Module																																																										
V	2014	Enclave	Body	Frontview Camera Module																																																										
V	2014	Enclave	Body	Theft Deterrent Module																																																										
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2015	Enclave	Chassis	Electronic Brake Control Module																																																										
V	2015	Enclave	Body	Body Control Module																																																										
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Enclave	Body	Passenger Presence Module																																																										
V	2015	Enclave	Body	Instrument Cluster																																																										
V	2015	Enclave	Body	Head-Up Display Module																																																										
V	2015	Enclave	Body	Headlamp Control Module																																																										
V	2015	Enclave	Body	Radio																																																										
V	2015	Enclave	Body	Rear Audio Control Module																																																										
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																																										
V	2015	Enclave	Body	Personal Audio Link Control Module																																																										
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Enclave	Body	HVAC Control Module																																																										
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																										
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2015	Enclave	Body	Liftgate Control Module																																																										
V	2015	Enclave	Body	Seat Memory Control Module																																																										
V	2015	Enclave	Body	Front Seat Heating Control Module																																																										
V	2015	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2015	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2015	Enclave	Body	Parking Assist Control Module																																																										
V	2015	Enclave	Body	Frontview Camera Module																																																										
V	2015	Enclave	Body	Theft Deterrent Module																																																										
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Enclave	Chassis	Electronic Brake Control Module																																																										
V	2016	Enclave	Body	Body Control Module																																																										
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Enclave	Body	Passenger Presence Module																																																										
V	2016	Enclave	Body	Instrument Cluster																																																										
V	2016	Enclave	Body	Head-Up Display Module																																																										
V	2016	Enclave	Body	Headlamp Control Module																																																										
V	2016	Enclave	Body	Radio																																																										
V	2016	Enclave	Body	Rear Audio Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
V	2016	Enclave	Body	Digital Radio Receiver Control Module																																																								
V	2016	Enclave	Body	Personal Audio Link Control Module																																																								
V	2016	Enclave	Body	Telematics Communication Interface Control Module																																																								
V	2016	Enclave	Body	HVAC Control Module																																																								
V	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																								
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																								
V	2016	Enclave	Body	Liftgate Control Module																																																								
V	2016	Enclave	Body	Seat Memory Control Module																																																								
V	2016	Enclave	Body	Front Seat Heating Control Module																																																								
V	2016	Enclave	Body	Right Side Object Detection Control Module																																																								
V	2016	Enclave	Body	Left Side Object Detection Control Module																																																								
V	2016	Enclave	Body	Remote Control Door Lock Receiver																																																								
V	2016	Enclave	Body	Parking Assist Control Module																																																								
V	2016	Enclave	Body	Frontview Camera Module																																																								
V	2016	Enclave	Body	Theft Deterrent Module																																																								
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																								
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																								
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module																																																								
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module																																																								
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module																																																								
X	2016	Envision	Chassis	Electronic Brake Control Module																																																								
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module																																																								
X	2016	Envision	Chassis	Power Steering Control Module																																																								
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module																																																								
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
X	2016	Envision	Body	Passenger Presence Module																																																								
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																								
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																								
X	2016	Envision	Body	Radio Controls																																																								
X	2016	Envision	Body	HVAC Controls																																																								
X	2016	Envision	Body	Video Processing Control Module								V	V	V	V	V																																												
X	2016	Envision	Body	Headlamp Control Module																																																								
X	2016	Envision	Body	Radio																																																								
X	2016	Envision	Body	Amplifier																																																								
X	2016	Envision	Body	Human Machine Interface Control Module																																																								
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7																																																								
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10																																																								
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)																																																								
X	2016	Envision	Body	Liftgate Control Module																																																								
X	2016	Envision	Body	Seat Memory Control Module - Driver																																																								
X	2016	Envision	Body	Keyless Entry Control Module																																																								
X	2016	Envision	Body	Right Side Object Detection Control Module																																																								
X	2016	Envision	Body	Left Side Object Detection Control Module																																																								
X	2016	Envision	Body	Parking Assist Control Module																																																								
X	2016	Envision	Body	Frontview Camera Module																																																								
X	2016	Envision	Body	Frontview Camera Module																																																								
X	2016	Envision	Body	Steering Column Lock Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
X	2016	Envision	Body	Power Supply Transformer																																																												
X	2016	Envision	Body	Long Range Radar Sensor Module		V																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																										
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2013	Encore	Powertrain	Fuel Pump Control Module																																																										
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module																																																										
J	2013	Encore	Chassis	Electronic Brake Control Module																																																										
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Encore	Chassis	Power Steering Control Module																																																										
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Encore	Body	Body Control Module																																																										
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Encore	Body	Passenger Presence Module																																																										
J	2013	Encore	Body	Instrument Cluster																																																										
J	2013	Encore	Body	Radio																																																										
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																										
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)																																																										
J	2013	Encore	Body	Seat Memory Control Module																																																										
J	2013	Encore	Body	Front Seat Heating Control Module																																																										
J	2013	Encore	Body	Parking Assist Control Module																																																										
J	2013	Encore	Body	Frontview Camera Module																																																										
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit																																																										
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2014	Encore	Powertrain	Chassis Control Module																																																										
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module																																																										
J	2014	Encore	Chassis	Electronic Brake Control Module																																																										
J	2014	Encore	Chassis	Power Steering Control Module																																																										
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Encore	Body	Body Control Module																																																										
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Encore	Body	Passenger Presence Module																																																										
J	2014	Encore	Body	Instrument Cluster																																																										
J	2014	Encore	Body	Radio Other																																																										
J	2014	Encore	Body	Radio (UF7)																																																										
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																										
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)																																																										
J	2014	Encore	Body	Seat Memory Control Module																																																										
J	2014	Encore	Body	Front Seat Heating Control Module																																																										
J	2014	Encore	Body	Left Side Object Detection Control Module																																																										
J	2014	Encore	Body	Parking Assist Control Module																																																										
J	2014	Encore	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																										
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2015	Encore	Powertrain	Chassis Control Module																																																										
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Encore	Chassis	Electronic Brake Control Module																																																										
J	2015	Encore	Chassis	Power Steering Control Module																																																										
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Encore	Body	Body Control Module																																																										
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Encore	Body	Passenger Presence Module																																																										
J	2015	Encore	Body	Instrument Cluster																																																										
J	2015	Encore	Body	Radio Other																																																										
J	2015	Encore	Body	Radio (UF7)																																																										
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																										
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)																																																										
J	2015	Encore	Body	Seat Memory Control Module																																																										
J	2015	Encore	Body	Front Seat Heating Control Module																																																										
J	2015	Encore	Body	Left Side Object Detection Control Module																																																										
J	2015	Encore	Body	Parking Assist Control Module																																																										
J	2015	Encore	Body	Frontview Camera Module																																																										
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																										
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2016	Encore	Powertrain	Chassis Control Module																																																										
J	2016	Encore	Chassis	Electronic Brake Control Module																																																										
J	2016	Encore	Chassis	Power Steering Control Module																																																										
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Encore	Body	Body Control Module																																																										
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Encore	Body	Passenger Presence Module																																																										
J	2016	Encore	Body	Instrument Cluster																																																										
J	2016	Encore	Body	Radio																																																										
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																										
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)																																																										
J	2016	Encore	Body	Seat Memory Control Module																																																										
J	2016	Encore	Body	Front Seat Heating Control Module																																																										
J	2016	Encore	Body	Left Side Object Detection Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2016	Encore	Body	Parking Assist Control Module																																																										
J	2016	Encore	Body	Frontview Camera Module																																																										
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2014	Enclave	Powertrain	Chassis Control Module																																																										
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
R	2014	Enclave	Chassis	Electronic Brake Control Module																																																										
R	2014	Enclave	Body	Body Control Module																																																										
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2014	Enclave	Body	Passenger Presence Module																																																										
R	2014	Enclave	Body	Instrument Cluster																																																										
R	2014	Enclave	Body	Headlamp Control Module																																																										
R	2014	Enclave	Body	Radio																																																										
R	2014	Enclave	Body	Rear Audio Control Module																																																										
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																																										
R	2014	Enclave	Body	Personal Audio Link Control Module																																																										
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	Enclave	Body	HVAC Control Module																																																										
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																										
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
R	2014	Enclave	Body	Liftgate Control Module																																																										
R	2014	Enclave	Body	Seat Memory Control Module																																																										
R	2014	Enclave	Body	Front Seat Heating Control Module																																																										
R	2014	Enclave	Body	Right Side Object Detection Control Module																																																										
R	2014	Enclave	Body	Left Side Object Detection Control Module																																																										
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																																										
R	2014	Enclave	Body	Parking Assist Control Module																																																										
R	2014	Enclave	Body	Frontview Camera Module																																																										
R	2014	Enclave	Body	Theft Deterrent Module		V																																																								
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
R	2015	Enclave	Chassis	Electronic Brake Control Module																																																										
R	2015	Enclave	Body	Body Control Module																																																										
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	Enclave	Body	Passenger Presence Module																																																										
R	2015	Enclave	Body	Instrument Cluster																																																										
R	2015	Enclave	Body	Head-Up Display Module																																																										
R	2015	Enclave	Body	Headlamp Control Module																																																										
R	2015	Enclave	Body	Radio																																																										
R	2015	Enclave	Body	Rear Audio Control Module																																																										
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																																										
R	2015	Enclave	Body	Personal Audio Link Control Module																																																										
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2015	Enclave	Body	HVAC Control Module																																																										
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																										
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
R	2015	Enclave	Body	Liftgate Control Module																																																										
R	2015	Enclave	Body	Seat Memory Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2015	Enclave	Body	Front Seat Heating Control Module																																																											
R	2015	Enclave	Body	Right Side Object Detection Control Module																																																											
R	2015	Enclave	Body	Left Side Object Detection Control Module																																																											
R	2015	Enclave	Body	Remote Control Door Lock Receiver																																																											
R	2015	Enclave	Body	Parking Assist Control Module																																																											
R	2015	Enclave	Body	Frontview Camera Module																																																											
R	2015	Enclave	Body	Theft Deterrent Module		V																																																									
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																											
R	2016	Enclave	Chassis	Electronic Brake Control Module																																																											
R	2016	Enclave	Body	Body Control Module																																																											
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2016	Enclave	Body	Passenger Presence Module																																																											
R	2016	Enclave	Body	Instrument Cluster																																																											
R	2016	Enclave	Body	Head-Up Display Module																																																											
R	2016	Enclave	Body	Headlamp Control Module																																																											
R	2016	Enclave	Body	Radio																																																											
R	2016	Enclave	Body	Rear Audio Control Module																																																											
R	2016	Enclave	Body	Digital Radio Receiver Control Module																																																											
R	2016	Enclave	Body	Personal Audio Link Control Module																																																											
R	2016	Enclave	Body	Telematics Communication Interface Control Module																																																											
R	2016	Enclave	Body	HVAC Control Module																																																											
R	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																											
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																											
R	2016	Enclave	Body	Liftgate Control Module																																																											
R	2016	Enclave	Body	Seat Memory Control Module																																																											
R	2016	Enclave	Body	Front Seat Heating Control Module																																																											
R	2016	Enclave	Body	Right Side Object Detection Control Module																																																											
R	2016	Enclave	Body	Left Side Object Detection Control Module																																																											
R	2016	Enclave	Body	Remote Control Door Lock Receiver																																																											
R	2016	Enclave	Body	Parking Assist Control Module																																																											
R	2016	Enclave	Body	Frontview Camera Module																																																											
R	2016	Enclave	Body	Theft Deterrent Module		V																																																									
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2014	Enclave	Powertrain	Chassis Control Module																																																											
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																											
V	2014	Enclave	Chassis	Electronic Brake Control Module																																																											
V	2014	Enclave	Body	Body Control Module																																																											
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
V	2014	Enclave	Body	Passenger Presence Module																																																											
V	2014	Enclave	Body	Instrument Cluster																																																											
V	2014	Enclave	Body	Headlamp Control Module																																																											
V	2014	Enclave	Body	Radio																																																											
V	2014	Enclave	Body	Rear Audio Control Module																																																											
V	2014	Enclave	Body	Digital Radio Receiver Control Module																																																											
V	2014	Enclave	Body	Personal Audio Link Control Module																																																											
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																											
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																											
V	2014	Enclave	Body	HVAC Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																										
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2014	Enclave	Body	Liftgate Control Module																																																										
V	2014	Enclave	Body	Seat Memory Control Module																																																										
V	2014	Enclave	Body	Front Seat Heating Control Module																																																										
V	2014	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2014	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2014	Enclave	Body	Parking Assist Control Module																																																										
V	2014	Enclave	Body	Frontview Camera Module																																																										
V	2014	Enclave	Body	Theft Deterrent Module		V																																																								
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2015	Enclave	Chassis	Electronic Brake Control Module																																																										
V	2015	Enclave	Body	Body Control Module																																																										
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Enclave	Body	Passenger Presence Module																																																										
V	2015	Enclave	Body	Instrument Cluster																																																										
V	2015	Enclave	Body	Head-Up Display Module																																																										
V	2015	Enclave	Body	Headlamp Control Module																																																										
V	2015	Enclave	Body	Radio																																																										
V	2015	Enclave	Body	Rear Audio Control Module																																																										
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																																										
V	2015	Enclave	Body	Personal Audio Link Control Module																																																										
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Enclave	Body	HVAC Control Module																																																										
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																										
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2015	Enclave	Body	Liftgate Control Module																																																										
V	2015	Enclave	Body	Seat Memory Control Module																																																										
V	2015	Enclave	Body	Front Seat Heating Control Module																																																										
V	2015	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2015	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2015	Enclave	Body	Parking Assist Control Module																																																										
V	2015	Enclave	Body	Frontview Camera Module																																																										
V	2015	Enclave	Body	Theft Deterrent Module		V																																																								
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Enclave	Chassis	Electronic Brake Control Module																																																										
V	2016	Enclave	Body	Body Control Module																																																										
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Enclave	Body	Passenger Presence Module																																																										
V	2016	Enclave	Body	Instrument Cluster																																																										
V	2016	Enclave	Body	Head-Up Display Module																																																										
V	2016	Enclave	Body	Headlamp Control Module																																																										
V	2016	Enclave	Body	Radio																																																										
V	2016	Enclave	Body	Rear Audio Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
V	2016	Enclave	Body	Digital Radio Receiver Control Module																																																										
V	2016	Enclave	Body	Personal Audio Link Control Module																																																											
V	2016	Enclave	Body	Telematics Communication Interface Control Module																																																											
V	2016	Enclave	Body	HVAC Control Module																																																											
V	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																											
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																											
V	2016	Enclave	Body	Liftgate Control Module																																																											
V	2016	Enclave	Body	Seat Memory Control Module																																																											
V	2016	Enclave	Body	Front Seat Heating Control Module																																																											
V	2016	Enclave	Body	Right Side Object Detection Control Module																																																											
V	2016	Enclave	Body	Left Side Object Detection Control Module																																																											
V	2016	Enclave	Body	Remote Control Door Lock Receiver																																																											
V	2016	Enclave	Body	Parking Assist Control Module																																																											
V	2016	Enclave	Body	Frontview Camera Module																																																											
V	2016	Enclave	Body	Theft Deterrent Module		V																																																									
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module																																																											
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module																																																											
X	2016	Envision	Chassis	Electronic Brake Control Module																																																											
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module																																																											
X	2016	Envision	Chassis	Power Steering Control Module																																																											
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module																																																											
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
X	2016	Envision	Body	Passenger Presence Module																																																											
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																											
X	2016	Envision	Body	Radio Controls																																																											
X	2016	Envision	Body	HVAC Controls																																																											
X	2016	Envision	Body	Video Processing Control Module																																																											
X	2016	Envision	Body	Headlamp Control Module																																																											
X	2016	Envision	Body	Radio																																																											
X	2016	Envision	Body	Amplifier																																																											
X	2016	Envision	Body	Human Machine Interface Control Module																																																											
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7																																																											
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10																																																											
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
X	2016	Envision	Body	Liftgate Control Module																																																											
X	2016	Envision	Body	Seat Memory Control Module - Driver																																																											
X	2016	Envision	Body	Keyless Entry Control Module																																																											
X	2016	Envision	Body	Right Side Object Detection Control Module																																																											
X	2016	Envision	Body	Left Side Object Detection Control Module																																																											
X	2016	Envision	Body	Parking Assist Control Module																																																											
X	2016	Envision	Body	Frontview Camera Module																																																											
X	2016	Envision	Body	Frontview Camera Module																																																											
X	2016	Envision	Body	Steering Column Lock Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
X	2016	Envision	Body	Power Supply Transformer																																																												
X	2016	Envision	Body	Long Range Radar Sensor Module																																																													

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																											
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																											
J	2013	Encore	Powertrain	Fuel Pump Control Module																																																												
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module																																																											
J	2013	Encore	Chassis	Electronic Brake Control Module																																																											
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2013	Encore	Chassis	Power Steering Control Module																																																											
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2013	Encore	Body	Body Control Module																																																											
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2013	Encore	Body	Passenger Presence Module																																																											
J	2013	Encore	Body	Instrument Cluster																																																											
J	2013	Encore	Body	Radio																																																											
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																											
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)																																																											
J	2013	Encore	Body	Seat Memory Control Module																																																											
J	2013	Encore	Body	Front Seat Heating Control Module																																																											
J	2013	Encore	Body	Parking Assist Control Module																																																											
J	2013	Encore	Body	Frontview Camera Module																																																											
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit																																																											
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																											
J	2014	Encore	Powertrain	Chassis Control Module																																																											
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module																																																											
J	2014	Encore	Chassis	Electronic Brake Control Module																																																											
J	2014	Encore	Chassis	Power Steering Control Module																																																											
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2014	Encore	Body	Body Control Module																																																											
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2014	Encore	Body	Passenger Presence Module																																																											
J	2014	Encore	Body	Instrument Cluster																																																											
J	2014	Encore	Body	Radio Other																																																											
J	2014	Encore	Body	Radio (UF7)																																																											
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																											
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)																																																											
J	2014	Encore	Body	Seat Memory Control Module																																																											
J	2014	Encore	Body	Front Seat Heating Control Module																																																											
J	2014	Encore	Body	Left Side Object Detection Control Module																																																											
J	2014	Encore	Body	Parking Assist Control Module																																																											
J	2014	Encore	Body	Frontview Camera Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																											
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																											
J	2015	Encore	Powertrain	Chassis Control Module																																																											
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module																																																											
J	2015	Encore	Chassis	Electronic Brake Control Module																																																											
J	2015	Encore	Chassis	Power Steering Control Module																																																											
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2015	Encore	Body	Body Control Module																																																											
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2015	Encore	Body	Passenger Presence Module																																																											
J	2015	Encore	Body	Instrument Cluster																																																											
J	2015	Encore	Body	Radio Other																																																											
J	2015	Encore	Body	Radio (UF7)																																																											
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																											
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																											
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)																																																											
J	2015	Encore	Body	Seat Memory Control Module																																																											
J	2015	Encore	Body	Front Seat Heating Control Module																																																											
J	2015	Encore	Body	Left Side Object Detection Control Module																																																											
J	2015	Encore	Body	Parking Assist Control Module																																																											
J	2015	Encore	Body	Frontview Camera Module																																																											
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																											
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																											
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																											
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																											
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																											
J	2016	Encore	Powertrain	Chassis Control Module																																																											
J	2016	Encore	Chassis	Electronic Brake Control Module																																																											
J	2016	Encore	Chassis	Power Steering Control Module																																																											
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Encore	Body	Body Control Module																																																											
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Encore	Body	Passenger Presence Module																																																											
J	2016	Encore	Body	Instrument Cluster																																																											
J	2016	Encore	Body	Radio																																																											
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																											
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																											
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)																																																											
J	2016	Encore	Body	Seat Memory Control Module																																																											
J	2016	Encore	Body	Front Seat Heating Control Module																																																											
J	2016	Encore	Body	Left Side Object Detection Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2016	Encore	Body	Parking Assist Control Module																																																										
J	2016	Encore	Body	Frontview Camera Module																																																										
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2014	Enclave	Powertrain	Chassis Control Module																																																										
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
R	2014	Enclave	Chassis	Electronic Brake Control Module																																																										
R	2014	Enclave	Body	Body Control Module																																																										
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2014	Enclave	Body	Passenger Presence Module																																																										
R	2014	Enclave	Body	Instrument Cluster																																																										
R	2014	Enclave	Body	Headlamp Control Module																																																										
R	2014	Enclave	Body	Radio																																																										
R	2014	Enclave	Body	Rear Audio Control Module																																																										
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																																										
R	2014	Enclave	Body	Personal Audio Link Control Module																																																										
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	Enclave	Body	HVAC Control Module																																																										
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																										
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
R	2014	Enclave	Body	Liftgate Control Module																																																										
R	2014	Enclave	Body	Seat Memory Control Module																																																										
R	2014	Enclave	Body	Front Seat Heating Control Module																																																										
R	2014	Enclave	Body	Right Side Object Detection Control Module																																																										
R	2014	Enclave	Body	Left Side Object Detection Control Module																																																										
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																																										
R	2014	Enclave	Body	Parking Assist Control Module																																																										
R	2014	Enclave	Body	Frontview Camera Module																																																										
R	2014	Enclave	Body	Theft Deterrent Module																																																										
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
R	2015	Enclave	Chassis	Electronic Brake Control Module																																																										
R	2015	Enclave	Body	Body Control Module																																																										
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	Enclave	Body	Passenger Presence Module																																																										
R	2015	Enclave	Body	Instrument Cluster																																																										
R	2015	Enclave	Body	Head-Up Display Module																																																										
R	2015	Enclave	Body	Headlamp Control Module																																																										
R	2015	Enclave	Body	Radio																																																										
R	2015	Enclave	Body	Rear Audio Control Module																																																										
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																																										
R	2015	Enclave	Body	Personal Audio Link Control Module																																																										
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2015	Enclave	Body	HVAC Control Module																																																										
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																										
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
R	2015	Enclave	Body	Liftgate Control Module																																																										
R	2015	Enclave	Body	Seat Memory Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2015	Enclave	Body	Front Seat Heating Control Module																																																										
R	2015	Enclave	Body	Right Side Object Detection Control Module																																																											
R	2015	Enclave	Body	Left Side Object Detection Control Module																																																											
R	2015	Enclave	Body	Remote Control Door Lock Receiver																																																											
R	2015	Enclave	Body	Parking Assist Control Module																																																											
R	2015	Enclave	Body	Frontview Camera Module																																																											
R	2015	Enclave	Body	Theft Deterrent Module																																																											
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																											
R	2016	Enclave	Chassis	Electronic Brake Control Module																																																											
R	2016	Enclave	Body	Body Control Module																																																											
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2016	Enclave	Body	Passenger Presence Module																																																											
R	2016	Enclave	Body	Instrument Cluster																																																											
R	2016	Enclave	Body	Head-Up Display Module																																																											
R	2016	Enclave	Body	Headlamp Control Module																																																											
R	2016	Enclave	Body	Radio																																																											
R	2016	Enclave	Body	Rear Audio Control Module																																																											
R	2016	Enclave	Body	Digital Radio Receiver Control Module																																																											
R	2016	Enclave	Body	Personal Audio Link Control Module																																																											
R	2016	Enclave	Body	Telematics Communication Interface Control Module																																																											
R	2016	Enclave	Body	HVAC Control Module																																																											
R	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																											
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																											
R	2016	Enclave	Body	Liftgate Control Module																																																											
R	2016	Enclave	Body	Seat Memory Control Module																																																											
R	2016	Enclave	Body	Front Seat Heating Control Module																																																											
R	2016	Enclave	Body	Right Side Object Detection Control Module																																																											
R	2016	Enclave	Body	Left Side Object Detection Control Module																																																											
R	2016	Enclave	Body	Remote Control Door Lock Receiver																																																											
R	2016	Enclave	Body	Parking Assist Control Module																																																											
R	2016	Enclave	Body	Frontview Camera Module																																																											
R	2016	Enclave	Body	Theft Deterrent Module																																																											
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2014	Enclave	Powertrain	Chassis Control Module																																																											
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																											
V	2014	Enclave	Chassis	Electronic Brake Control Module																																																											
V	2014	Enclave	Body	Body Control Module																																																											
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
V	2014	Enclave	Body	Passenger Presence Module																																																											
V	2014	Enclave	Body	Instrument Cluster																																																											
V	2014	Enclave	Body	Headlamp Control Module																																																											
V	2014	Enclave	Body	Radio																																																											
V	2014	Enclave	Body	Rear Audio Control Module																																																											
V	2014	Enclave	Body	Digital Radio Receiver Control Module																																																											
V	2014	Enclave	Body	Personal Audio Link Control Module																																																											
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																											
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																											
V	2014	Enclave	Body	HVAC Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																									
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																									
V	2014	Enclave	Body	Liftgate Control Module																																																									
V	2014	Enclave	Body	Seat Memory Control Module																																																									
V	2014	Enclave	Body	Front Seat Heating Control Module																																																									
V	2014	Enclave	Body	Right Side Object Detection Control Module																																																									
V	2014	Enclave	Body	Left Side Object Detection Control Module																																																									
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																																									
V	2014	Enclave	Body	Parking Assist Control Module																																																									
V	2014	Enclave	Body	Frontview Camera Module																																																									
V	2014	Enclave	Body	Theft Deterrent Module																																																									
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																									
V	2015	Enclave	Chassis	Electronic Brake Control Module																																																									
V	2015	Enclave	Body	Body Control Module																																																									
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2015	Enclave	Body	Passenger Presence Module																																																									
V	2015	Enclave	Body	Instrument Cluster																																																									
V	2015	Enclave	Body	Head-Up Display Module																																																									
V	2015	Enclave	Body	Headlamp Control Module																																																									
V	2015	Enclave	Body	Radio																																																									
V	2015	Enclave	Body	Rear Audio Control Module																																																									
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																																									
V	2015	Enclave	Body	Personal Audio Link Control Module																																																									
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2015	Enclave	Body	HVAC Control Module																																																									
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																									
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																									
V	2015	Enclave	Body	Liftgate Control Module																																																									
V	2015	Enclave	Body	Seat Memory Control Module																																																									
V	2015	Enclave	Body	Front Seat Heating Control Module																																																									
V	2015	Enclave	Body	Right Side Object Detection Control Module																																																									
V	2015	Enclave	Body	Left Side Object Detection Control Module																																																									
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																																									
V	2015	Enclave	Body	Parking Assist Control Module																																																									
V	2015	Enclave	Body	Frontview Camera Module																																																									
V	2015	Enclave	Body	Theft Deterrent Module																																																									
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																									
V	2016	Enclave	Chassis	Electronic Brake Control Module																																																									
V	2016	Enclave	Body	Body Control Module																																																									
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2016	Enclave	Body	Passenger Presence Module																																																									
V	2016	Enclave	Body	Instrument Cluster																																																									
V	2016	Enclave	Body	Head-Up Display Module																																																									
V	2016	Enclave	Body	Headlamp Control Module																																																									
V	2016	Enclave	Body	Radio																																																									
V	2016	Enclave	Body	Rear Audio Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
V	2016	Enclave	Body	Digital Radio Receiver Control Module																																																										
V	2016	Enclave	Body	Personal Audio Link Control Module																																																										
V	2016	Enclave	Body	Telematics Communication Interface Control Module																																																										
V	2016	Enclave	Body	HVAC Control Module																																																										
V	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Enclave	Body	Liftgate Control Module																																																										
V	2016	Enclave	Body	Seat Memory Control Module																																																										
V	2016	Enclave	Body	Front Seat Heating Control Module																																																										
V	2016	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2016	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2016	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2016	Enclave	Body	Parking Assist Control Module																																																										
V	2016	Enclave	Body	Frontview Camera Module																																																										
V	2016	Enclave	Body	Theft Deterrent Module																																																										
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module																																																										
X	2016	Envision	Chassis	Electronic Brake Control Module																																																										
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module																																																										
X	2016	Envision	Chassis	Power Steering Control Module																																																										
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module																																																										
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
X	2016	Envision	Body	Passenger Presence Module																																																										
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																										
X	2016	Envision	Body	Radio Controls																																																										
X	2016	Envision	Body	HVAC Controls																																																										
X	2016	Envision	Body	Video Processing Control Module																																																										
X	2016	Envision	Body	Headlamp Control Module																																																										
X	2016	Envision	Body	Radio																																																										
X	2016	Envision	Body	Amplifier																																																										
X	2016	Envision	Body	Human Machine Interface Control Module																																																										
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7																																																										
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10																																																										
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
X	2016	Envision	Body	Liftgate Control Module																																																										
X	2016	Envision	Body	Seat Memory Control Module - Driver																																																										
X	2016	Envision	Body	Keyless Entry Control Module																																																										
X	2016	Envision	Body	Right Side Object Detection Control Module																																																										
X	2016	Envision	Body	Left Side Object Detection Control Module																																																										
X	2016	Envision	Body	Parking Assist Control Module																																																										
X	2016	Envision	Body	Frontview Camera Module																																																										
X	2016	Envision	Body	Frontview Camera Module																																																										
X	2016	Envision	Body	Steering Column Lock Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
X	2016	Envision	Body	Power Supply Transformer																																																												
X	2016	Envision	Body	Long Range Radar Sensor Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																													
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																													
J	2013	Encore	Powertrain	Fuel Pump Control Module																																																													
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module																																																													
J	2013	Encore	Chassis	Electronic Brake Control Module																																																													
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2013	Encore	Chassis	Power Steering Control Module																																																													
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2013	Encore	Body	Body Control Module																																																													
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2013	Encore	Body	Passenger Presence Module																																																													
J	2013	Encore	Body	Instrument Cluster																																																													
J	2013	Encore	Body	Radio																																																												
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																												
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)																																																												
J	2013	Encore	Body	Seat Memory Control Module																																																												
J	2013	Encore	Body	Front Seat Heating Control Module																																																												
J	2013	Encore	Body	Parking Assist Control Module																																																												
J	2013	Encore	Body	Frontview Camera Module																																																												
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit																																																												
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																												
J	2014	Encore	Powertrain	Chassis Control Module																																																													
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module																																																												
J	2014	Encore	Chassis	Electronic Brake Control Module																																																												
J	2014	Encore	Chassis	Power Steering Control Module																																																												
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Encore	Body	Body Control Module																																																												
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Encore	Body	Passenger Presence Module																																																												
J	2014	Encore	Body	Instrument Cluster																																																												
J	2014	Encore	Body	Radio Other																																																												
J	2014	Encore	Body	Radio (UF7)																																																												
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																												
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)																																																												
J	2014	Encore	Body	Seat Memory Control Module																																																												
J	2014	Encore	Body	Front Seat Heating Control Module																																																												
J	2014	Encore	Body	Left Side Object Detection Control Module																																																												
J	2014	Encore	Body	Parking Assist Control Module																																																												
J	2014	Encore	Body	Frontview Camera Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																													
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																													
J	2015	Encore	Powertrain	Chassis Control Module																																																													
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module																																																													
J	2015	Encore	Chassis	Electronic Brake Control Module																																																													
J	2015	Encore	Chassis	Power Steering Control Module																																																													
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2015	Encore	Body	Body Control Module																																																													
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2015	Encore	Body	Passenger Presence Module																																																													
J	2015	Encore	Body	Instrument Cluster																																																													
J	2015	Encore	Body	Radio Other																																																												
J	2015	Encore	Body	Radio (UF7)																																																												
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																												
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																												
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)																																																												
J	2015	Encore	Body	Seat Memory Control Module																																																												
J	2015	Encore	Body	Front Seat Heating Control Module																																																												
J	2015	Encore	Body	Left Side Object Detection Control Module																																																												
J	2015	Encore	Body	Parking Assist Control Module																																																												
J	2015	Encore	Body	Frontview Camera Module																																																												
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																												
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																												
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																												
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																												
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																												
J	2016	Encore	Powertrain	Chassis Control Module																																																													
J	2016	Encore	Chassis	Electronic Brake Control Module																																																													
J	2016	Encore	Chassis	Power Steering Control Module																																																													
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2016	Encore	Body	Body Control Module																																																													
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2016	Encore	Body	Passenger Presence Module																																																													
J	2016	Encore	Body	Instrument Cluster																																																													
J	2016	Encore	Body	Radio																																																												
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																												
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																												
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)																																																												
J	2016	Encore	Body	Seat Memory Control Module																																																												
J	2016	Encore	Body	Front Seat Heating Control Module																																																												
J	2016	Encore	Body	Left Side Object Detection Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2016	Encore	Body	Parking Assist Control Module																																																												
J	2016	Encore	Body	Frontview Camera Module																																																												
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2014	Enclave	Powertrain	Chassis Control Module																																																												
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
R	2014	Enclave	Chassis	Electronic Brake Control Module																																																												
R	2014	Enclave	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V	V												
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Enclave	Body	Passenger Presence Module																																																												
R	2014	Enclave	Body	Instrument Cluster																																																												
R	2014	Enclave	Body	Headlamp Control Module																																																												
R	2014	Enclave	Body	Radio																																																												
R	2014	Enclave	Body	Rear Audio Control Module																																																												
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																																												
R	2014	Enclave	Body	Personal Audio Link Control Module																																																												
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Enclave	Body	HVAC Control Module																																																						V						
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																												
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
R	2014	Enclave	Body	Liftgate Control Module																																																							V	V	V	V		
R	2014	Enclave	Body	Seat Memory Control Module																																																										V	V
R	2014	Enclave	Body	Front Seat Heating Control Module																																																												
R	2014	Enclave	Body	Right Side Object Detection Control Module																																																												
R	2014	Enclave	Body	Left Side Object Detection Control Module																																																												
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																																												
R	2014	Enclave	Body	Parking Assist Control Module																																																												
R	2014	Enclave	Body	Frontview Camera Module																																																												
R	2014	Enclave	Body	Theft Deterrent Module																																																												
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
R	2015	Enclave	Chassis	Electronic Brake Control Module																																																												
R	2015	Enclave	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V	V												
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Enclave	Body	Passenger Presence Module																																																												
R	2015	Enclave	Body	Instrument Cluster																																																												
R	2015	Enclave	Body	Head-Up Display Module																																																												
R	2015	Enclave	Body	Headlamp Control Module																																																												
R	2015	Enclave	Body	Radio																																																												
R	2015	Enclave	Body	Rear Audio Control Module																																																												
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																																												
R	2015	Enclave	Body	Personal Audio Link Control Module																																																												
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2015	Enclave	Body	HVAC Control Module																																																						V						
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																												
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
R	2015	Enclave	Body	Liftgate Control Module																																																							V	V	V	V		
R	2015	Enclave	Body	Seat Memory Control Module																																																										V	V

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2015	Enclave	Body	Front Seat Heating Control Module																																																												
R	2015	Enclave	Body	Right Side Object Detection Control Module																																																												
R	2015	Enclave	Body	Left Side Object Detection Control Module																																																												
R	2015	Enclave	Body	Remote Control Door Lock Receiver																																																												
R	2015	Enclave	Body	Parking Assist Control Module																																																												
R	2015	Enclave	Body	Frontview Camera Module																																																												
R	2015	Enclave	Body	Theft Deterrent Module																																																												
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
R	2016	Enclave	Chassis	Electronic Brake Control Module																																																												
R	2016	Enclave	Body	Body Control Module																																					V	V	V	V	V	V	V	V	V	V	V													
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2016	Enclave	Body	Passenger Presence Module																																																												
R	2016	Enclave	Body	Instrument Cluster																																																												
R	2016	Enclave	Body	Head-Up Display Module																																																												
R	2016	Enclave	Body	Headlamp Control Module																																																												
R	2016	Enclave	Body	Radio																																																												
R	2016	Enclave	Body	Rear Audio Control Module																																																												
R	2016	Enclave	Body	Digital Radio Receiver Control Module																																																												
R	2016	Enclave	Body	Personal Audio Link Control Module																																																												
R	2016	Enclave	Body	Telematics Communication Interface Control Module																																																												
R	2016	Enclave	Body	HVAC Control Module																																																	V											
R	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																												
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
R	2016	Enclave	Body	Liftgate Control Module																																																			V	V	V	V				
R	2016	Enclave	Body	Seat Memory Control Module																																																									V	V
R	2016	Enclave	Body	Front Seat Heating Control Module																																																												
R	2016	Enclave	Body	Right Side Object Detection Control Module																																																												
R	2016	Enclave	Body	Left Side Object Detection Control Module																																																												
R	2016	Enclave	Body	Remote Control Door Lock Receiver																																																												
R	2016	Enclave	Body	Parking Assist Control Module																																																												
R	2016	Enclave	Body	Frontview Camera Module																																																												
R	2016	Enclave	Body	Theft Deterrent Module																																																												
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2014	Enclave	Powertrain	Chassis Control Module																																																												
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
V	2014	Enclave	Chassis	Electronic Brake Control Module																																																												
V	2014	Enclave	Body	Body Control Module																																					V	V	V	V	V	V	V	V	V	V	V													
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2014	Enclave	Body	Passenger Presence Module																																																												
V	2014	Enclave	Body	Instrument Cluster																																																												
V	2014	Enclave	Body	Headlamp Control Module																																																												
V	2014	Enclave	Body	Radio																																																												
V	2014	Enclave	Body	Rear Audio Control Module																																																												
V	2014	Enclave	Body	Digital Radio Receiver Control Module																																																												
V	2014	Enclave	Body	Personal Audio Link Control Module																																																												
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2014	Enclave	Body	HVAC Control Module																																																	V											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																												
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
V	2014	Enclave	Body	Liftgate Control Module																																																				V	V	V	V			
V	2014	Enclave	Body	Seat Memory Control Module																																																						V	V
V	2014	Enclave	Body	Front Seat Heating Control Module																																																										
V	2014	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2014	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2014	Enclave	Body	Parking Assist Control Module																																																										
V	2014	Enclave	Body	Frontview Camera Module																																																										
V	2014	Enclave	Body	Theft Deterrent Module																																																										
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2015	Enclave	Chassis	Electronic Brake Control Module																																																										
V	2015	Enclave	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Enclave	Body	Passenger Presence Module																																																		V								
V	2015	Enclave	Body	Instrument Cluster																																																										
V	2015	Enclave	Body	Head-Up Display Module																																																										
V	2015	Enclave	Body	Headlamp Control Module																																																										
V	2015	Enclave	Body	Radio																																																										
V	2015	Enclave	Body	Rear Audio Control Module																																																										
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																																										
V	2015	Enclave	Body	Personal Audio Link Control Module																																																										
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Enclave	Body	HVAC Control Module																																																	V								
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																										
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2015	Enclave	Body	Liftgate Control Module																																																			V	V	V	V			
V	2015	Enclave	Body	Seat Memory Control Module																																																						V	V
V	2015	Enclave	Body	Front Seat Heating Control Module																																																										
V	2015	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2015	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2015	Enclave	Body	Parking Assist Control Module																																																										
V	2015	Enclave	Body	Frontview Camera Module																																																										
V	2015	Enclave	Body	Theft Deterrent Module																																																										
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Enclave	Chassis	Electronic Brake Control Module																																																										
V	2016	Enclave	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Enclave	Body	Passenger Presence Module																																																		V								
V	2016	Enclave	Body	Instrument Cluster																																																										
V	2016	Enclave	Body	Head-Up Display Module																																																										
V	2016	Enclave	Body	Headlamp Control Module																																																										
V	2016	Enclave	Body	Radio																																																										
V	2016	Enclave	Body	Rear Audio Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
V	2016	Enclave	Body	Digital Radio Receiver Control Module																																																												
V	2016	Enclave	Body	Personal Audio Link Control Module																																																												
V	2016	Enclave	Body	Telematics Communication Interface Control Module																																																												
V	2016	Enclave	Body	HVAC Control Module																																																												
V	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																												
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
V	2016	Enclave	Body	Liftgate Control Module																																																												
V	2016	Enclave	Body	Seat Memory Control Module																																																												
V	2016	Enclave	Body	Front Seat Heating Control Module																																																												
V	2016	Enclave	Body	Right Side Object Detection Control Module																																																												
V	2016	Enclave	Body	Left Side Object Detection Control Module																																																												
V	2016	Enclave	Body	Remote Control Door Lock Receiver																																																												
V	2016	Enclave	Body	Parking Assist Control Module																																																												
V	2016	Enclave	Body	Frontview Camera Module																																																												
V	2016	Enclave	Body	Theft Deterrent Module																																																												
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																												
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																												
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module																																																												
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module																																																												
X	2016	Envision	Chassis	Electronic Brake Control Module																																																												
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module																																																												
X	2016	Envision	Chassis	Power Steering Control Module																																																												
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module																																																												
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
X	2016	Envision	Body	Passenger Presence Module																																																												
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																												
X	2016	Envision	Body	Radio Controls																																																												
X	2016	Envision	Body	HVAC Controls																																																												
X	2016	Envision	Body	Video Processing Control Module																																																												
X	2016	Envision	Body	Headlamp Control Module																																																												
X	2016	Envision	Body	Radio																																																												
X	2016	Envision	Body	Amplifier																																																												
X	2016	Envision	Body	Human Machine Interface Control Module																																																												
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7																																																												
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10																																																												
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
X	2016	Envision	Body	Liftgate Control Module																																																												
X	2016	Envision	Body	Seat Memory Control Module - Driver																																																												
X	2016	Envision	Body	Keyless Entry Control Module																																																												
X	2016	Envision	Body	Right Side Object Detection Control Module																																																												
X	2016	Envision	Body	Left Side Object Detection Control Module																																																												
X	2016	Envision	Body	Parking Assist Control Module																																																												
X	2016	Envision	Body	Frontview Camera Module																																																												
X	2016	Envision	Body	Frontview Camera Module																																																												
X	2016	Envision	Body	Steering Column Lock Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | New Actuator Setup Procedure | VSCM Data | Signal Data | VSCM Disable Reason | VSCM Power Steering Reset | Range Measurements | Module Data | Inhibit Data | Calibrate Module | Exh. Aftertreatment Data | Parking Brake Shoe Service Reset | Parking Brake Actuator DTC Reset | Parking Brake Switch Procedure | Charging Info | RVS Disable 1 History | RVS Disable 2 History | RVS Disable 3 History | RVS Disable 4 History | RVS Disable 5 History | RVS Disable 6 History | RVS Disable 7 History | Passenger presence system learn | Signal Type | Module ID Information | Open History Data | Close History Data | Last Open Fail Data | Last Close Fail Data | Obstacle Detect Opening Data | Obstacle Detect Closing Data | LGM Open/Close Test | Deployment Loop 1-14 Resistance | Deployment Loop 15-18 Resistance | Deployment Loop Configuration | Sensor Configuration | Parking Brake Calibration | CAN Bus Communication | Remote Vehicle Start Data | Remote Vehicle Start Disable History 1 Data | Remote Vehicle Start Disable History 2 Data | Remote Vehicle Start Disable History 3 Data | Remote Vehicle Start Disable History 4 Data | Remote Vehicle Start Disable History 5 Data | Remote Vehicle Start Disable History 6 Data | Remote Vehicle Start Disable History 7 Data | Steering Wheel Control Switches | Vehicle Access | Passenger Presence Data | HVAC Door Position Data | A/C Permission Data | Last Liftgate Close Malfunction Data | Last Liftgate Open Malfunction Data | Engineering Data 1 | Engineering Data 2 | Seat Position Data | Steering Column Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																									
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																									
J	2013	Encore	Powertrain	Fuel Pump Control Module																																																									
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module																																																									
J	2013	Encore	Chassis	Electronic Brake Control Module																																																									
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2013	Encore	Chassis	Power Steering Control Module																																																									
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2013	Encore	Body	Body Control Module																																																									
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2013	Encore	Body	Passenger Presence Module																																																									
J	2013	Encore	Body	Instrument Cluster																																																									
J	2013	Encore	Body	Radio																																																									
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																									
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)																																																									
J	2013	Encore	Body	Seat Memory Control Module																																																									
J	2013	Encore	Body	Front Seat Heating Control Module																																																									
J	2013	Encore	Body	Parking Assist Control Module																																																									
J	2013	Encore	Body	Frontview Camera Module																																																									
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit																																																									
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																									
J	2014	Encore	Powertrain	Chassis Control Module																																																									
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module																																																									
J	2014	Encore	Chassis	Electronic Brake Control Module																																																									
J	2014	Encore	Chassis	Power Steering Control Module																																																									
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2014	Encore	Body	Body Control Module																																																									
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2014	Encore	Body	Passenger Presence Module																																																									
J	2014	Encore	Body	Instrument Cluster																																																									
J	2014	Encore	Body	Radio Other																																																									
J	2014	Encore	Body	Radio (UF7)																																																									
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9																																																									
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																									
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)																																																									
J	2014	Encore	Body	Seat Memory Control Module																																																									
J	2014	Encore	Body	Front Seat Heating Control Module																																																									
J	2014	Encore	Body	Left Side Object Detection Control Module																																																									
J	2014	Encore	Body	Parking Assist Control Module																																																									
J	2014	Encore	Body	Frontview Camera Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																									
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																									
J	2015	Encore	Powertrain	Chassis Control Module																																																									
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module																																																									
J	2015	Encore	Chassis	Electronic Brake Control Module																																																									
J	2015	Encore	Chassis	Power Steering Control Module																																																									
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2015	Encore	Body	Body Control Module																																																									
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2015	Encore	Body	Passenger Presence Module																																																									
J	2015	Encore	Body	Instrument Cluster																																																									
J	2015	Encore	Body	Radio Other																																																									
J	2015	Encore	Body	Radio (UF7)																																																									
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																									
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																									
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)																																																									
J	2015	Encore	Body	Seat Memory Control Module																																																									
J	2015	Encore	Body	Front Seat Heating Control Module																																																									
J	2015	Encore	Body	Left Side Object Detection Control Module																																																									
J	2015	Encore	Body	Parking Assist Control Module																																																									
J	2015	Encore	Body	Frontview Camera Module																																																									
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																									
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																									
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																									
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																									
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																									
J	2016	Encore	Powertrain	Chassis Control Module																																																									
J	2016	Encore	Chassis	Electronic Brake Control Module																																																									
J	2016	Encore	Chassis	Power Steering Control Module																																																									
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2016	Encore	Body	Body Control Module																																																									
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2016	Encore	Body	Passenger Presence Module																																																									
J	2016	Encore	Body	Instrument Cluster																																																									
J	2016	Encore	Body	Radio																																																									
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																									
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																									
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)																																																									
J	2016	Encore	Body	Seat Memory Control Module																																																									
J	2016	Encore	Body	Front Seat Heating Control Module																																																									
J	2016	Encore	Body	Left Side Object Detection Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2016	Encore	Body	Parking Assist Control Module																																																										
J	2016	Encore	Body	Frontview Camera Module																																																										
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2014	Enclave	Powertrain	Chassis Control Module																																																										
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
R	2014	Enclave	Chassis	Electronic Brake Control Module																																																										
R	2014	Enclave	Body	Body Control Module																																																										
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2014	Enclave	Body	Passenger Presence Module																																																										
R	2014	Enclave	Body	Instrument Cluster																																																										
R	2014	Enclave	Body	Headlamp Control Module																																																										
R	2014	Enclave	Body	Radio																																																										
R	2014	Enclave	Body	Rear Audio Control Module																																																										
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																																										
R	2014	Enclave	Body	Personal Audio Link Control Module																																																										
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	Enclave	Body	HVAC Control Module																																																										
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																										
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
R	2014	Enclave	Body	Liftgate Control Module																																												V															
R	2014	Enclave	Body	Seat Memory Control Module	V	V	V																																																							
R	2014	Enclave	Body	Front Seat Heating Control Module																																																										
R	2014	Enclave	Body	Right Side Object Detection Control Module																																																										
R	2014	Enclave	Body	Left Side Object Detection Control Module																																																										
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																																										
R	2014	Enclave	Body	Parking Assist Control Module																																																										
R	2014	Enclave	Body	Frontview Camera Module																																																										
R	2014	Enclave	Body	Theft Deterrent Module				V	V																																																					
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
R	2015	Enclave	Chassis	Electronic Brake Control Module																																																										
R	2015	Enclave	Body	Body Control Module																																																										
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	Enclave	Body	Passenger Presence Module																																																										
R	2015	Enclave	Body	Instrument Cluster																																																										
R	2015	Enclave	Body	Head-Up Display Module																																																										
R	2015	Enclave	Body	Headlamp Control Module																																																										
R	2015	Enclave	Body	Radio																																																										
R	2015	Enclave	Body	Rear Audio Control Module																																																										
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																																										
R	2015	Enclave	Body	Personal Audio Link Control Module																																																										
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2015	Enclave	Body	HVAC Control Module																																																										
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																										
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
R	2015	Enclave	Body	Liftgate Control Module																																										V															
R	2015	Enclave	Body	Seat Memory Control Module	V	V	V																																																							

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2015	Enclave	Body	Front Seat Heating Control Module																																																										
R	2015	Enclave	Body	Right Side Object Detection Control Module																																																										
R	2015	Enclave	Body	Left Side Object Detection Control Module																																																										
R	2015	Enclave	Body	Remote Control Door Lock Receiver																																																										
R	2015	Enclave	Body	Parking Assist Control Module																																																										
R	2015	Enclave	Body	Frontview Camera Module																																																										
R	2015	Enclave	Body	Theft Deterrent Module				V	V																																																					
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
R	2016	Enclave	Chassis	Electronic Brake Control Module																																																										
R	2016	Enclave	Body	Body Control Module																																																										
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Enclave	Body	Passenger Presence Module																																																										
R	2016	Enclave	Body	Instrument Cluster																																																										
R	2016	Enclave	Body	Head-Up Display Module																																																										
R	2016	Enclave	Body	Headlamp Control Module																																																										
R	2016	Enclave	Body	Radio																																																										
R	2016	Enclave	Body	Rear Audio Control Module																																																										
R	2016	Enclave	Body	Digital Radio Receiver Control Module																																																										
R	2016	Enclave	Body	Personal Audio Link Control Module																																																										
R	2016	Enclave	Body	Telematics Communication Interface Control Module																																																										
R	2016	Enclave	Body	HVAC Control Module																																																										
R	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Enclave	Body	Liftgate Control Module																																											V															
R	2016	Enclave	Body	Seat Memory Control Module	V	V	V																																																							
R	2016	Enclave	Body	Front Seat Heating Control Module																																																										
R	2016	Enclave	Body	Right Side Object Detection Control Module																																																										
R	2016	Enclave	Body	Left Side Object Detection Control Module																																																										
R	2016	Enclave	Body	Remote Control Door Lock Receiver																																																										
R	2016	Enclave	Body	Parking Assist Control Module																																																										
R	2016	Enclave	Body	Frontview Camera Module																																																										
R	2016	Enclave	Body	Theft Deterrent Module				V	V																																																					
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2014	Enclave	Powertrain	Chassis Control Module																																																										
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2014	Enclave	Chassis	Electronic Brake Control Module																																																										
V	2014	Enclave	Body	Body Control Module																																																										
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2014	Enclave	Body	Passenger Presence Module																																																										
V	2014	Enclave	Body	Instrument Cluster																																																										
V	2014	Enclave	Body	Headlamp Control Module																																																										
V	2014	Enclave	Body	Radio																																																										
V	2014	Enclave	Body	Rear Audio Control Module																																																										
V	2014	Enclave	Body	Digital Radio Receiver Control Module																																																										
V	2014	Enclave	Body	Personal Audio Link Control Module																																																										
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2014	Enclave	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																										
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2014	Enclave	Body	Liftgate Control Module																																										V															
V	2014	Enclave	Body	Seat Memory Control Module	V	V	V																																																						
V	2014	Enclave	Body	Front Seat Heating Control Module																																																									
V	2014	Enclave	Body	Right Side Object Detection Control Module																																																									
V	2014	Enclave	Body	Left Side Object Detection Control Module																																																									
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																																									
V	2014	Enclave	Body	Parking Assist Control Module																																																									
V	2014	Enclave	Body	Frontview Camera Module																																																									
V	2014	Enclave	Body	Theft Deterrent Module				V	V																																																				
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																									
V	2015	Enclave	Chassis	Electronic Brake Control Module																																																									
V	2015	Enclave	Body	Body Control Module																																																									
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2015	Enclave	Body	Passenger Presence Module																																																									
V	2015	Enclave	Body	Instrument Cluster																																																									
V	2015	Enclave	Body	Head-Up Display Module																																																									
V	2015	Enclave	Body	Headlamp Control Module																																																									
V	2015	Enclave	Body	Radio																																																									
V	2015	Enclave	Body	Rear Audio Control Module																																																									
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																																									
V	2015	Enclave	Body	Personal Audio Link Control Module																																																									
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2015	Enclave	Body	HVAC Control Module																																																									
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																									
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																									
V	2015	Enclave	Body	Liftgate Control Module																																										V															
V	2015	Enclave	Body	Seat Memory Control Module	V	V	V																																																						
V	2015	Enclave	Body	Front Seat Heating Control Module																																																									
V	2015	Enclave	Body	Right Side Object Detection Control Module																																																									
V	2015	Enclave	Body	Left Side Object Detection Control Module																																																									
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																																									
V	2015	Enclave	Body	Parking Assist Control Module																																																									
V	2015	Enclave	Body	Frontview Camera Module																																																									
V	2015	Enclave	Body	Theft Deterrent Module				V	V																																																				
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																									
V	2016	Enclave	Chassis	Electronic Brake Control Module																																																									
V	2016	Enclave	Body	Body Control Module																																																									
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2016	Enclave	Body	Passenger Presence Module																																																									
V	2016	Enclave	Body	Instrument Cluster																																																									
V	2016	Enclave	Body	Head-Up Display Module																																																									
V	2016	Enclave	Body	Headlamp Control Module																																																									
V	2016	Enclave	Body	Radio																																																									
V	2016	Enclave	Body	Rear Audio Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
V	2016	Enclave	Body	Digital Radio Receiver Control Module																																																										
V	2016	Enclave	Body	Personal Audio Link Control Module																																																										
V	2016	Enclave	Body	Telematics Communication Interface Control Module																																																										
V	2016	Enclave	Body	HVAC Control Module																																																										
V	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Enclave	Body	Liftgate Control Module																																											V															
V	2016	Enclave	Body	Seat Memory Control Module	V	V	V																																																							
V	2016	Enclave	Body	Front Seat Heating Control Module																																																										
V	2016	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2016	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2016	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2016	Enclave	Body	Parking Assist Control Module																																																										
V	2016	Enclave	Body	Frontview Camera Module																																																										
V	2016	Enclave	Body	Theft Deterrent Module				V	V																																																					
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module																																																										
X	2016	Envision	Chassis	Electronic Brake Control Module																																		V	V																					
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module																																																										
X	2016	Envision	Chassis	Power Steering Control Module																																																										
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module																																																										
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																				V																					
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																				V																					
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
X	2016	Envision	Body	Passenger Presence Module																																																										
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																										
X	2016	Envision	Body	Radio Controls																																																										
X	2016	Envision	Body	HVAC Controls																																																										
X	2016	Envision	Body	Video Processing Control Module																																					V																					
X	2016	Envision	Body	Headlamp Control Module																																																										
X	2016	Envision	Body	Radio																																																										
X	2016	Envision	Body	Amplifier																																																										
X	2016	Envision	Body	Human Machine Interface Control Module																																																										
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7																																																										
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10																																																										
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
X	2016	Envision	Body	Liftgate Control Module																																						V	V	V	V	V	V															
X	2016	Envision	Body	Seat Memory Control Module - Driver																																																										
X	2016	Envision	Body	Keyless Entry Control Module																																																										
X	2016	Envision	Body	Right Side Object Detection Control Module																																																										
X	2016	Envision	Body	Left Side Object Detection Control Module																																																										
X	2016	Envision	Body	Parking Assist Control Module																																																										
X	2016	Envision	Body	Frontview Camera Module																																																										
X	2016	Envision	Body	Frontview Camera Module																																																										
X	2016	Envision	Body	Steering Column Lock Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
X	2016	Envision	Body	Power Supply Transformer																																																										
X	2016	Envision	Body	Long Range Radar Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																													
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																													
J	2013	Encore	Powertrain	Fuel Pump Control Module																																																													
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module																																																													
J	2013	Encore	Chassis	Electronic Brake Control Module																																																													
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2013	Encore	Chassis	Power Steering Control Module																																																													
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2013	Encore	Body	Body Control Module																																																													
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2013	Encore	Body	Passenger Presence Module																																																													
J	2013	Encore	Body	Instrument Cluster																																																													
J	2013	Encore	Body	Radio																																																													
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9																																																													
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10																																																													
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																													
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)																																																													
J	2013	Encore	Body	Seat Memory Control Module																																																													
J	2013	Encore	Body	Front Seat Heating Control Module																																																													
J	2013	Encore	Body	Parking Assist Control Module																																																													
J	2013	Encore	Body	Frontview Camera Module																																																													
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit																																																													
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																													
J	2014	Encore	Powertrain	Chassis Control Module																																																													
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module																																																													
J	2014	Encore	Chassis	Electronic Brake Control Module																																																													
J	2014	Encore	Chassis	Power Steering Control Module																																																													
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2014	Encore	Body	Body Control Module																																																													
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2014	Encore	Body	Passenger Presence Module																																																													
J	2014	Encore	Body	Instrument Cluster																																																													
J	2014	Encore	Body	Radio Other																																																													
J	2014	Encore	Body	Radio (UF7)																																																													
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9																																																													
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10																																																													
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																													
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)																																																													
J	2014	Encore	Body	Seat Memory Control Module																																																													
J	2014	Encore	Body	Front Seat Heating Control Module																																																													
J	2014	Encore	Body	Left Side Object Detection Control Module																																																													
J	2014	Encore	Body	Parking Assist Control Module																																																													
J	2014	Encore	Body	Frontview Camera Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																													
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																													
J	2015	Encore	Powertrain	Chassis Control Module																																																													
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module																																																													
J	2015	Encore	Chassis	Electronic Brake Control Module																																																													
J	2015	Encore	Chassis	Power Steering Control Module																																																													
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2015	Encore	Body	Body Control Module																																																													
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2015	Encore	Body	Passenger Presence Module																																																													
J	2015	Encore	Body	Instrument Cluster																																																													
J	2015	Encore	Body	Radio Other																																																												
J	2015	Encore	Body	Radio (UF7)																																																												
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																												
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																												
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)																																																												
J	2015	Encore	Body	Seat Memory Control Module																																																												
J	2015	Encore	Body	Front Seat Heating Control Module																																																												
J	2015	Encore	Body	Left Side Object Detection Control Module																																																												
J	2015	Encore	Body	Parking Assist Control Module																																																												
J	2015	Encore	Body	Frontview Camera Module																																																												
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																												
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																												
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																												
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																												
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																												
J	2016	Encore	Powertrain	Chassis Control Module																																																													
J	2016	Encore	Chassis	Electronic Brake Control Module																																																													
J	2016	Encore	Chassis	Power Steering Control Module																																																													
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2016	Encore	Body	Body Control Module																																																												
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Encore	Body	Passenger Presence Module																																																												
J	2016	Encore	Body	Instrument Cluster																																																												
J	2016	Encore	Body	Radio																																																												
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																												
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																												
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)																																																												
J	2016	Encore	Body	Seat Memory Control Module																																																												
J	2016	Encore	Body	Front Seat Heating Control Module																																																												
J	2016	Encore	Body	Left Side Object Detection Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2016	Encore	Body	Parking Assist Control Module																																																											
J	2016	Encore	Body	Frontview Camera Module																																																												
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2014	Enclave	Powertrain	Chassis Control Module																																																												
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
R	2014	Enclave	Chassis	Electronic Brake Control Module																																																												
R	2014	Enclave	Body	Body Control Module																																																												
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Enclave	Body	Passenger Presence Module																																																												
R	2014	Enclave	Body	Instrument Cluster																																																												
R	2014	Enclave	Body	Headlamp Control Module																																																												
R	2014	Enclave	Body	Radio																																																												
R	2014	Enclave	Body	Rear Audio Control Module																																																												
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																																												
R	2014	Enclave	Body	Personal Audio Link Control Module																																																												
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Enclave	Body	HVAC Control Module																																																												
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																												
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
R	2014	Enclave	Body	Liftgate Control Module																																																												
R	2014	Enclave	Body	Seat Memory Control Module																																																												
R	2014	Enclave	Body	Front Seat Heating Control Module																																																												
R	2014	Enclave	Body	Right Side Object Detection Control Module																																																												
R	2014	Enclave	Body	Left Side Object Detection Control Module																																																												
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																																												
R	2014	Enclave	Body	Parking Assist Control Module																																																												
R	2014	Enclave	Body	Frontview Camera Module																																																												
R	2014	Enclave	Body	Theft Deterrent Module																																																												
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
R	2015	Enclave	Chassis	Electronic Brake Control Module																																																												
R	2015	Enclave	Body	Body Control Module																																																												
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Enclave	Body	Passenger Presence Module																																																												
R	2015	Enclave	Body	Instrument Cluster																																																												
R	2015	Enclave	Body	Head-Up Display Module																																																												
R	2015	Enclave	Body	Headlamp Control Module																																																												
R	2015	Enclave	Body	Radio																																																												
R	2015	Enclave	Body	Rear Audio Control Module																																																												
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																																												
R	2015	Enclave	Body	Personal Audio Link Control Module																																																												
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2015	Enclave	Body	HVAC Control Module																																																												
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																												
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
R	2015	Enclave	Body	Liftgate Control Module																																																												
R	2015	Enclave	Body	Seat Memory Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2015	Enclave	Body	Front Seat Heating Control Module																																																												
R	2015	Enclave	Body	Right Side Object Detection Control Module																																																												
R	2015	Enclave	Body	Left Side Object Detection Control Module																																																												
R	2015	Enclave	Body	Remote Control Door Lock Receiver																																																												
R	2015	Enclave	Body	Parking Assist Control Module																																																												
R	2015	Enclave	Body	Frontview Camera Module																																																												
R	2015	Enclave	Body	Theft Deterrent Module																																																												
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
R	2016	Enclave	Chassis	Electronic Brake Control Module																																																												
R	2016	Enclave	Body	Body Control Module																																																												
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2016	Enclave	Body	Passenger Presence Module																																																												
R	2016	Enclave	Body	Instrument Cluster																																																												
R	2016	Enclave	Body	Head-Up Display Module																																																												
R	2016	Enclave	Body	Headlamp Control Module																																																												
R	2016	Enclave	Body	Radio																																																												
R	2016	Enclave	Body	Rear Audio Control Module																																																												
R	2016	Enclave	Body	Digital Radio Receiver Control Module																																																												
R	2016	Enclave	Body	Personal Audio Link Control Module																																																												
R	2016	Enclave	Body	Telematics Communication Interface Control Module																																																												
R	2016	Enclave	Body	HVAC Control Module																																																												
R	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																												
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
R	2016	Enclave	Body	Liftgate Control Module																																																												
R	2016	Enclave	Body	Seat Memory Control Module																																																												
R	2016	Enclave	Body	Front Seat Heating Control Module																																																												
R	2016	Enclave	Body	Right Side Object Detection Control Module																																																												
R	2016	Enclave	Body	Left Side Object Detection Control Module																																																												
R	2016	Enclave	Body	Remote Control Door Lock Receiver																																																												
R	2016	Enclave	Body	Parking Assist Control Module																																																												
R	2016	Enclave	Body	Frontview Camera Module																																																												
R	2016	Enclave	Body	Theft Deterrent Module																																																												
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2014	Enclave	Powertrain	Chassis Control Module																																																												
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
V	2014	Enclave	Chassis	Electronic Brake Control Module																																																												
V	2014	Enclave	Body	Body Control Module																																																												
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2014	Enclave	Body	Passenger Presence Module																																																												
V	2014	Enclave	Body	Instrument Cluster																																																												
V	2014	Enclave	Body	Headlamp Control Module																																																												
V	2014	Enclave	Body	Radio																																																												
V	2014	Enclave	Body	Rear Audio Control Module																																																												
V	2014	Enclave	Body	Digital Radio Receiver Control Module																																																												
V	2014	Enclave	Body	Personal Audio Link Control Module																																																												
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2014	Enclave	Body	HVAC Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																												
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
V	2014	Enclave	Body	Liftgate Control Module																																																												
V	2014	Enclave	Body	Seat Memory Control Module																																																												
V	2014	Enclave	Body	Front Seat Heating Control Module																																																												
V	2014	Enclave	Body	Right Side Object Detection Control Module																																																												
V	2014	Enclave	Body	Left Side Object Detection Control Module																																																												
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																																												
V	2014	Enclave	Body	Parking Assist Control Module																																																												
V	2014	Enclave	Body	Frontview Camera Module																																																												
V	2014	Enclave	Body	Theft Deterrent Module																																																												
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
V	2015	Enclave	Chassis	Electronic Brake Control Module																																																												
V	2015	Enclave	Body	Body Control Module																																																												
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2015	Enclave	Body	Passenger Presence Module																																																												
V	2015	Enclave	Body	Instrument Cluster																																																												
V	2015	Enclave	Body	Head-Up Display Module																																																												
V	2015	Enclave	Body	Headlamp Control Module																																																												
V	2015	Enclave	Body	Radio																																																											
V	2015	Enclave	Body	Rear Audio Control Module																																																												
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																																												
V	2015	Enclave	Body	Personal Audio Link Control Module																																																												
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2015	Enclave	Body	HVAC Control Module																																																												
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																												
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
V	2015	Enclave	Body	Liftgate Control Module																																																												
V	2015	Enclave	Body	Seat Memory Control Module																																																												
V	2015	Enclave	Body	Front Seat Heating Control Module																																																												
V	2015	Enclave	Body	Right Side Object Detection Control Module																																																												
V	2015	Enclave	Body	Left Side Object Detection Control Module																																																												
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																																												
V	2015	Enclave	Body	Parking Assist Control Module																																																												
V	2015	Enclave	Body	Frontview Camera Module																																																												
V	2015	Enclave	Body	Theft Deterrent Module																																																												
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
V	2016	Enclave	Chassis	Electronic Brake Control Module																																																												
V	2016	Enclave	Body	Body Control Module																																																												
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2016	Enclave	Body	Passenger Presence Module																																																												
V	2016	Enclave	Body	Instrument Cluster																																																												
V	2016	Enclave	Body	Head-Up Display Module																																																												
V	2016	Enclave	Body	Headlamp Control Module																																																												
V	2016	Enclave	Body	Radio																																																											
V	2016	Enclave	Body	Rear Audio Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
V	2016	Enclave	Body	Digital Radio Receiver Control Module																																																														
V	2016	Enclave	Body	Personal Audio Link Control Module																																																														
V	2016	Enclave	Body	Telematics Communication Interface Control Module																																																														
V	2016	Enclave	Body	HVAC Control Module																																																														
V	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																														
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																														
V	2016	Enclave	Body	Liftgate Control Module																																																														
V	2016	Enclave	Body	Seat Memory Control Module																																																														
V	2016	Enclave	Body	Front Seat Heating Control Module																																																														
V	2016	Enclave	Body	Right Side Object Detection Control Module																																																														
V	2016	Enclave	Body	Left Side Object Detection Control Module																																																														
V	2016	Enclave	Body	Remote Control Door Lock Receiver																																																														
V	2016	Enclave	Body	Parking Assist Control Module																																																														
V	2016	Enclave	Body	Frontview Camera Module																																																														
V	2016	Enclave	Body	Theft Deterrent Module																																																														
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																														
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																														
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module																																																														
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module																																																														
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module																																																														
X	2016	Envision	Chassis	Electronic Brake Control Module																																																														
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module																																																														
X	2016	Envision	Chassis	Power Steering Control Module																																																														
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module																																																														
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
X	2016	Envision	Body	Passenger Presence Module																																																														
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																														
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																														
X	2016	Envision	Body	Radio Controls																																																														
X	2016	Envision	Body	HVAC Controls																																																														
X	2016	Envision	Body	Video Processing Control Module																																																														
X	2016	Envision	Body	Headlamp Control Module																																																														
X	2016	Envision	Body	Radio																																																														
X	2016	Envision	Body	Amplifier																																																														
X	2016	Envision	Body	Human Machine Interface Control Module																																																														
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7																																																														
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10																																																														
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)																																																														
X	2016	Envision	Body	Liftgate Control Module																																																														
X	2016	Envision	Body	Seat Memory Control Module - Driver																																																														
X	2016	Envision	Body	Keyless Entry Control Module																																																														
X	2016	Envision	Body	Right Side Object Detection Control Module																																																														
X	2016	Envision	Body	Left Side Object Detection Control Module																																																														
X	2016	Envision	Body	Parking Assist Control Module																																																														
X	2016	Envision	Body	Frontview Camera Module																																																														
X	2016	Envision	Body	Frontview Camera Module																																																														
X	2016	Envision	Body	Steering Column Lock Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
X	2016	Envision	Body	Power Supply Transformer																																																														
X	2016	Envision	Body	Long Range Radar Sensor Module																																																														

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																												
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																												
J	2013	Encore	Powertrain	Fuel Pump Control Module																																																													
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module																																																												
J	2013	Encore	Chassis	Electronic Brake Control Module																																																												
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2013	Encore	Chassis	Power Steering Control Module																																																												
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2013	Encore	Body	Body Control Module																																																												
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2013	Encore	Body	Passenger Presence Module																																																												
J	2013	Encore	Body	Instrument Cluster																																																												
J	2013	Encore	Body	Radio																																																												
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																												
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)																																																												
J	2013	Encore	Body	Seat Memory Control Module																																																												
J	2013	Encore	Body	Front Seat Heating Control Module																																																												
J	2013	Encore	Body	Parking Assist Control Module																																																												
J	2013	Encore	Body	Frontview Camera Module																																																												
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit																																																												
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																												
J	2014	Encore	Powertrain	Chassis Control Module																																																												
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module																																																												
J	2014	Encore	Chassis	Electronic Brake Control Module																																																												
J	2014	Encore	Chassis	Power Steering Control Module																																																												
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Encore	Body	Body Control Module																																																												
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Encore	Body	Passenger Presence Module																																																												
J	2014	Encore	Body	Instrument Cluster																																																												
J	2014	Encore	Body	Radio Other																																																												
J	2014	Encore	Body	Radio (UF7)																																																												
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																												
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)																																																												
J	2014	Encore	Body	Seat Memory Control Module																																																												
J	2014	Encore	Body	Front Seat Heating Control Module																																																												
J	2014	Encore	Body	Left Side Object Detection Control Module																																																												
J	2014	Encore	Body	Parking Assist Control Module																																																												
J	2014	Encore	Body	Frontview Camera Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																												
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																												
J	2015	Encore	Powertrain	Chassis Control Module																																																												
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module																																																												
J	2015	Encore	Chassis	Electronic Brake Control Module																																																												
J	2015	Encore	Chassis	Power Steering Control Module																																																												
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2015	Encore	Body	Body Control Module																																																												
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2015	Encore	Body	Passenger Presence Module																																																												
J	2015	Encore	Body	Instrument Cluster																																																												
J	2015	Encore	Body	Radio Other																																																												
J	2015	Encore	Body	Radio (UF7)																																																												
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																												
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																												
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)																																																												
J	2015	Encore	Body	Seat Memory Control Module																																																												
J	2015	Encore	Body	Front Seat Heating Control Module																																																												
J	2015	Encore	Body	Left Side Object Detection Control Module																																																												
J	2015	Encore	Body	Parking Assist Control Module																																																												
J	2015	Encore	Body	Frontview Camera Module																																																												
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																												
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																												
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																												
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																												
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																												
J	2016	Encore	Powertrain	Chassis Control Module																																																												
J	2016	Encore	Chassis	Electronic Brake Control Module																																																												
J	2016	Encore	Chassis	Power Steering Control Module																																																												
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Encore	Body	Body Control Module																																																												
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Encore	Body	Passenger Presence Module																																																												
J	2016	Encore	Body	Instrument Cluster																																																												
J	2016	Encore	Body	Radio																																																												
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																												
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																												
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)																																																												
J	2016	Encore	Body	Seat Memory Control Module																																																												
J	2016	Encore	Body	Front Seat Heating Control Module																																																												
J	2016	Encore	Body	Left Side Object Detection Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2016	Encore	Body	Parking Assist Control Module																																																											
J	2016	Encore	Body	Frontview Camera Module																																																												
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2014	Enclave	Powertrain	Chassis Control Module																																																												
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
R	2014	Enclave	Chassis	Electronic Brake Control Module																																																												
R	2014	Enclave	Body	Body Control Module																																																												
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Enclave	Body	Passenger Presence Module																																																												
R	2014	Enclave	Body	Instrument Cluster																																																												
R	2014	Enclave	Body	Headlamp Control Module																																																												
R	2014	Enclave	Body	Radio																																																												
R	2014	Enclave	Body	Rear Audio Control Module																																																												
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																																												
R	2014	Enclave	Body	Personal Audio Link Control Module																																																												
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Enclave	Body	HVAC Control Module																											V																																		
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																												
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
R	2014	Enclave	Body	Liftgate Control Module																																																												
R	2014	Enclave	Body	Seat Memory Control Module																																																												
R	2014	Enclave	Body	Front Seat Heating Control Module																																																												
R	2014	Enclave	Body	Right Side Object Detection Control Module																																																												
R	2014	Enclave	Body	Left Side Object Detection Control Module																																																												
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																																												
R	2014	Enclave	Body	Parking Assist Control Module																																																												
R	2014	Enclave	Body	Frontview Camera Module																																																												
R	2014	Enclave	Body	Theft Deterrent Module																																																												
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
R	2015	Enclave	Chassis	Electronic Brake Control Module																																																												
R	2015	Enclave	Body	Body Control Module																																																												
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Enclave	Body	Passenger Presence Module																																																												
R	2015	Enclave	Body	Instrument Cluster																																																												
R	2015	Enclave	Body	Head-Up Display Module																																																												
R	2015	Enclave	Body	Headlamp Control Module																																																												
R	2015	Enclave	Body	Radio																																																												
R	2015	Enclave	Body	Rear Audio Control Module																																																												
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																																												
R	2015	Enclave	Body	Personal Audio Link Control Module																																																												
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2015	Enclave	Body	HVAC Control Module																											V																																		
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																												
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
R	2015	Enclave	Body	Liftgate Control Module																																																												
R	2015	Enclave	Body	Seat Memory Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2015	Enclave	Body	Front Seat Heating Control Module																																																											
R	2015	Enclave	Body	Right Side Object Detection Control Module																																																												
R	2015	Enclave	Body	Left Side Object Detection Control Module																																																												
R	2015	Enclave	Body	Remote Control Door Lock Receiver																																																												
R	2015	Enclave	Body	Parking Assist Control Module																																																												
R	2015	Enclave	Body	Frontview Camera Module																																																												
R	2015	Enclave	Body	Theft Deterrent Module																																																												
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
R	2016	Enclave	Chassis	Electronic Brake Control Module																																																												
R	2016	Enclave	Body	Body Control Module																																																												
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2016	Enclave	Body	Passenger Presence Module																																																												
R	2016	Enclave	Body	Instrument Cluster																																																												
R	2016	Enclave	Body	Head-Up Display Module																																																												
R	2016	Enclave	Body	Headlamp Control Module																																																												
R	2016	Enclave	Body	Radio																																																												
R	2016	Enclave	Body	Rear Audio Control Module																																																												
R	2016	Enclave	Body	Digital Radio Receiver Control Module																																																												
R	2016	Enclave	Body	Personal Audio Link Control Module																																																												
R	2016	Enclave	Body	Telematics Communication Interface Control Module																																																												
R	2016	Enclave	Body	HVAC Control Module																											V																																	
R	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																												
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
R	2016	Enclave	Body	Liftgate Control Module																																																												
R	2016	Enclave	Body	Seat Memory Control Module																																																												
R	2016	Enclave	Body	Front Seat Heating Control Module																																																												
R	2016	Enclave	Body	Right Side Object Detection Control Module																																																												
R	2016	Enclave	Body	Left Side Object Detection Control Module																																																												
R	2016	Enclave	Body	Remote Control Door Lock Receiver																																																												
R	2016	Enclave	Body	Parking Assist Control Module																																																												
R	2016	Enclave	Body	Frontview Camera Module																																																												
R	2016	Enclave	Body	Theft Deterrent Module																																																												
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2014	Enclave	Powertrain	Chassis Control Module																																																												
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
V	2014	Enclave	Chassis	Electronic Brake Control Module																																																												
V	2014	Enclave	Body	Body Control Module																																																												
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2014	Enclave	Body	Passenger Presence Module																																																												
V	2014	Enclave	Body	Instrument Cluster																																																												
V	2014	Enclave	Body	Headlamp Control Module																																																												
V	2014	Enclave	Body	Radio																																																												
V	2014	Enclave	Body	Rear Audio Control Module																																																												
V	2014	Enclave	Body	Digital Radio Receiver Control Module																																																												
V	2014	Enclave	Body	Personal Audio Link Control Module																																																												
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2014	Enclave	Body	HVAC Control Module																											V																																	

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																										
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2014	Enclave	Body	Liftgate Control Module																																																										
V	2014	Enclave	Body	Seat Memory Control Module																																																										
V	2014	Enclave	Body	Front Seat Heating Control Module																																																										
V	2014	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2014	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2014	Enclave	Body	Parking Assist Control Module																																																										
V	2014	Enclave	Body	Frontview Camera Module																																																										
V	2014	Enclave	Body	Theft Deterrent Module																																																										
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2015	Enclave	Chassis	Electronic Brake Control Module																																																										
V	2015	Enclave	Body	Body Control Module																																																										
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Enclave	Body	Passenger Presence Module																																																										
V	2015	Enclave	Body	Instrument Cluster																																																										
V	2015	Enclave	Body	Head-Up Display Module																																																										
V	2015	Enclave	Body	Headlamp Control Module																																																										
V	2015	Enclave	Body	Radio																																																										
V	2015	Enclave	Body	Rear Audio Control Module																																																										
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																																										
V	2015	Enclave	Body	Personal Audio Link Control Module																																																										
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Enclave	Body	HVAC Control Module																											V																															
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																										
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2015	Enclave	Body	Liftgate Control Module																																																										
V	2015	Enclave	Body	Seat Memory Control Module																																																										
V	2015	Enclave	Body	Front Seat Heating Control Module																																																										
V	2015	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2015	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2015	Enclave	Body	Parking Assist Control Module																																																										
V	2015	Enclave	Body	Frontview Camera Module																																																										
V	2015	Enclave	Body	Theft Deterrent Module																																																										
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Enclave	Chassis	Electronic Brake Control Module																																																										
V	2016	Enclave	Body	Body Control Module																																																										
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Enclave	Body	Passenger Presence Module																																																										
V	2016	Enclave	Body	Instrument Cluster																																																										
V	2016	Enclave	Body	Head-Up Display Module																																																										
V	2016	Enclave	Body	Headlamp Control Module																																																										
V	2016	Enclave	Body	Radio																																																										
V	2016	Enclave	Body	Rear Audio Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
V	2016	Enclave	Body	Digital Radio Receiver Control Module																																																											
V	2016	Enclave	Body	Personal Audio Link Control Module																																																												
V	2016	Enclave	Body	Telematics Communication Interface Control Module																																																												
V	2016	Enclave	Body	HVAC Control Module																											V																																		
V	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																												
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
V	2016	Enclave	Body	Liftgate Control Module																																																												
V	2016	Enclave	Body	Seat Memory Control Module																																																												
V	2016	Enclave	Body	Front Seat Heating Control Module																																																												
V	2016	Enclave	Body	Right Side Object Detection Control Module																																																												
V	2016	Enclave	Body	Left Side Object Detection Control Module																																																												
V	2016	Enclave	Body	Remote Control Door Lock Receiver																																																												
V	2016	Enclave	Body	Parking Assist Control Module																																																												
V	2016	Enclave	Body	Frontview Camera Module																																																												
V	2016	Enclave	Body	Theft Deterrent Module																																																												
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																												
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																												
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module																																																												
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module																																																												
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module																																																												
X	2016	Envision	Chassis	Electronic Brake Control Module																																																												
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module																																																												
X	2016	Envision	Chassis	Power Steering Control Module																																																												
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module																																																												
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
X	2016	Envision	Body	Passenger Presence Module																																																												
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																												
X	2016	Envision	Body	Radio Controls																																																												
X	2016	Envision	Body	HVAC Controls																																																												
X	2016	Envision	Body	Video Processing Control Module																																																												
X	2016	Envision	Body	Headlamp Control Module																																																												
X	2016	Envision	Body	Radio																																																												
X	2016	Envision	Body	Amplifier																																																												
X	2016	Envision	Body	Human Machine Interface Control Module																																																												
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7																																																												
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10																																																												
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
X	2016	Envision	Body	Liftgate Control Module																																																												
X	2016	Envision	Body	Seat Memory Control Module - Driver																																																												
X	2016	Envision	Body	Keyless Entry Control Module																																																												
X	2016	Envision	Body	Right Side Object Detection Control Module																																																												
X	2016	Envision	Body	Left Side Object Detection Control Module																																																												
X	2016	Envision	Body	Parking Assist Control Module																				V																																								
X	2016	Envision	Body	Frontview Camera Module																																																												
X	2016	Envision	Body	Frontview Camera Module																																																												
X	2016	Envision	Body	Steering Column Lock Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
X	2016	Envision	Body	Power Supply Transformer																																																												
X	2016	Envision	Body	Long Range Radar Sensor Module																																																													

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																											
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																											
J	2013	Encore	Powertrain	Fuel Pump Control Module																																																												
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module																																																											
J	2013	Encore	Chassis	Electronic Brake Control Module																																																											
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2013	Encore	Chassis	Power Steering Control Module																																																											
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2013	Encore	Body	Body Control Module																																																											
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2013	Encore	Body	Passenger Presence Module																																																											
J	2013	Encore	Body	Instrument Cluster																																																											
J	2013	Encore	Body	Radio																																																											
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																											
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)																																																											
J	2013	Encore	Body	Seat Memory Control Module																																																											
J	2013	Encore	Body	Front Seat Heating Control Module																																																											
J	2013	Encore	Body	Parking Assist Control Module																																																											
J	2013	Encore	Body	Frontview Camera Module																																																											
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit																																																											
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																											
J	2014	Encore	Powertrain	Chassis Control Module																																																											
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module																																																											
J	2014	Encore	Chassis	Electronic Brake Control Module																																																											
J	2014	Encore	Chassis	Power Steering Control Module																																																											
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2014	Encore	Body	Body Control Module																																																											
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2014	Encore	Body	Passenger Presence Module																																																											
J	2014	Encore	Body	Instrument Cluster																																																											
J	2014	Encore	Body	Radio Other																																																											
J	2014	Encore	Body	Radio (UF7)																																																											
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																											
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)																																																											
J	2014	Encore	Body	Seat Memory Control Module																																																											
J	2014	Encore	Body	Front Seat Heating Control Module																																																											
J	2014	Encore	Body	Left Side Object Detection Control Module																																																											
J	2014	Encore	Body	Parking Assist Control Module																																																											
J	2014	Encore	Body	Frontview Camera Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																									
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																									
J	2015	Encore	Powertrain	Chassis Control Module																																																									
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module																																																									
J	2015	Encore	Chassis	Electronic Brake Control Module																																																									
J	2015	Encore	Chassis	Power Steering Control Module																																																									
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2015	Encore	Body	Body Control Module																																																									
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2015	Encore	Body	Passenger Presence Module																																																									
J	2015	Encore	Body	Instrument Cluster																																																									
J	2015	Encore	Body	Radio Other																																																									
J	2015	Encore	Body	Radio (UF7)																																																									
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																									
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																									
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)																																																									
J	2015	Encore	Body	Seat Memory Control Module																																																									
J	2015	Encore	Body	Front Seat Heating Control Module																																																									
J	2015	Encore	Body	Left Side Object Detection Control Module																																																									
J	2015	Encore	Body	Parking Assist Control Module																																																									
J	2015	Encore	Body	Frontview Camera Module																																																									
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																									
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																									
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																									
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																									
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																									
J	2016	Encore	Powertrain	Chassis Control Module																																																									
J	2016	Encore	Chassis	Electronic Brake Control Module																																																									
J	2016	Encore	Chassis	Power Steering Control Module																																																									
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2016	Encore	Body	Body Control Module																																																									
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2016	Encore	Body	Passenger Presence Module																																																									
J	2016	Encore	Body	Instrument Cluster																																																									
J	2016	Encore	Body	Radio																																																									
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																									
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																									
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)																																																									
J	2016	Encore	Body	Seat Memory Control Module																																																									
J	2016	Encore	Body	Front Seat Heating Control Module																																																									
J	2016	Encore	Body	Left Side Object Detection Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2016	Encore	Body	Parking Assist Control Module																																																										
J	2016	Encore	Body	Frontview Camera Module																																																										
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2014	Enclave	Powertrain	Chassis Control Module																																																										
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
R	2014	Enclave	Chassis	Electronic Brake Control Module																																																										
R	2014	Enclave	Body	Body Control Module																																																										
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2014	Enclave	Body	Passenger Presence Module																																																										
R	2014	Enclave	Body	Instrument Cluster																																																										
R	2014	Enclave	Body	Headlamp Control Module																																																										
R	2014	Enclave	Body	Radio																																																										
R	2014	Enclave	Body	Rear Audio Control Module																																																										
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																																										
R	2014	Enclave	Body	Personal Audio Link Control Module																																																										
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	Enclave	Body	HVAC Control Module																																																										
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																										
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
R	2014	Enclave	Body	Liftgate Control Module																																																										
R	2014	Enclave	Body	Seat Memory Control Module																																																										
R	2014	Enclave	Body	Front Seat Heating Control Module																																																										
R	2014	Enclave	Body	Right Side Object Detection Control Module																																																										
R	2014	Enclave	Body	Left Side Object Detection Control Module																																																										
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																																										
R	2014	Enclave	Body	Parking Assist Control Module																																																										
R	2014	Enclave	Body	Frontview Camera Module																																																										
R	2014	Enclave	Body	Theft Deterrent Module																																																										
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
R	2015	Enclave	Chassis	Electronic Brake Control Module																																																										
R	2015	Enclave	Body	Body Control Module																																																										
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	Enclave	Body	Passenger Presence Module																																																										
R	2015	Enclave	Body	Instrument Cluster																																																										
R	2015	Enclave	Body	Head-Up Display Module																																																										
R	2015	Enclave	Body	Headlamp Control Module																																																										
R	2015	Enclave	Body	Radio																																																										
R	2015	Enclave	Body	Rear Audio Control Module																																																										
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																																										
R	2015	Enclave	Body	Personal Audio Link Control Module																																																										
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2015	Enclave	Body	HVAC Control Module																																																										
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																										
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
R	2015	Enclave	Body	Liftgate Control Module																																																										
R	2015	Enclave	Body	Seat Memory Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2015	Enclave	Body	Front Seat Heating Control Module																																																												
R	2015	Enclave	Body	Right Side Object Detection Control Module																																																												
R	2015	Enclave	Body	Left Side Object Detection Control Module																																																												
R	2015	Enclave	Body	Remote Control Door Lock Receiver																																																												
R	2015	Enclave	Body	Parking Assist Control Module																																																												
R	2015	Enclave	Body	Frontview Camera Module																																																												
R	2015	Enclave	Body	Theft Deterrent Module																																																												
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
R	2016	Enclave	Chassis	Electronic Brake Control Module																																																												
R	2016	Enclave	Body	Body Control Module																																																												
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2016	Enclave	Body	Passenger Presence Module																																																												
R	2016	Enclave	Body	Instrument Cluster																																																												
R	2016	Enclave	Body	Head-Up Display Module																																																												
R	2016	Enclave	Body	Headlamp Control Module																																																												
R	2016	Enclave	Body	Radio																																																												
R	2016	Enclave	Body	Rear Audio Control Module																																																												
R	2016	Enclave	Body	Digital Radio Receiver Control Module																																																												
R	2016	Enclave	Body	Personal Audio Link Control Module																																																												
R	2016	Enclave	Body	Telematics Communication Interface Control Module																																																												
R	2016	Enclave	Body	HVAC Control Module																																																												
R	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																												
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																												
R	2016	Enclave	Body	Liftgate Control Module																																																												
R	2016	Enclave	Body	Seat Memory Control Module																																																												
R	2016	Enclave	Body	Front Seat Heating Control Module																																																												
R	2016	Enclave	Body	Right Side Object Detection Control Module																																																												
R	2016	Enclave	Body	Left Side Object Detection Control Module																																																												
R	2016	Enclave	Body	Remote Control Door Lock Receiver																																																												
R	2016	Enclave	Body	Parking Assist Control Module																																																												
R	2016	Enclave	Body	Frontview Camera Module																																																												
R	2016	Enclave	Body	Theft Deterrent Module																																																												
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2014	Enclave	Powertrain	Chassis Control Module																																																												
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																												
V	2014	Enclave	Chassis	Electronic Brake Control Module																																																												
V	2014	Enclave	Body	Body Control Module																																																												
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2014	Enclave	Body	Passenger Presence Module																																																												
V	2014	Enclave	Body	Instrument Cluster																																																												
V	2014	Enclave	Body	Headlamp Control Module																																																												
V	2014	Enclave	Body	Radio																																																											
V	2014	Enclave	Body	Rear Audio Control Module																																																												
V	2014	Enclave	Body	Digital Radio Receiver Control Module																																																												
V	2014	Enclave	Body	Personal Audio Link Control Module																																																												
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2014	Enclave	Body	HVAC Control Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																										
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2014	Enclave	Body	Liftgate Control Module																																																										
V	2014	Enclave	Body	Seat Memory Control Module																																																										
V	2014	Enclave	Body	Front Seat Heating Control Module																																																										
V	2014	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2014	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2014	Enclave	Body	Parking Assist Control Module																																																										
V	2014	Enclave	Body	Frontview Camera Module																																																										
V	2014	Enclave	Body	Theft Deterrent Module																																																										
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2015	Enclave	Chassis	Electronic Brake Control Module																																																										
V	2015	Enclave	Body	Body Control Module																																																										
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Enclave	Body	Passenger Presence Module																																																										
V	2015	Enclave	Body	Instrument Cluster																																																										
V	2015	Enclave	Body	Head-Up Display Module																																																										
V	2015	Enclave	Body	Headlamp Control Module																																																										
V	2015	Enclave	Body	Radio																																																										
V	2015	Enclave	Body	Rear Audio Control Module																																																										
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																																										
V	2015	Enclave	Body	Personal Audio Link Control Module																																																										
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Enclave	Body	HVAC Control Module																																																										
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																										
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2015	Enclave	Body	Liftgate Control Module																																																										
V	2015	Enclave	Body	Seat Memory Control Module																																																										
V	2015	Enclave	Body	Front Seat Heating Control Module																																																										
V	2015	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2015	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2015	Enclave	Body	Parking Assist Control Module																																																										
V	2015	Enclave	Body	Frontview Camera Module																																																										
V	2015	Enclave	Body	Theft Deterrent Module																																																										
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Enclave	Chassis	Electronic Brake Control Module																																																										
V	2016	Enclave	Body	Body Control Module																																																										
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Enclave	Body	Passenger Presence Module																																																										
V	2016	Enclave	Body	Instrument Cluster																																																										
V	2016	Enclave	Body	Head-Up Display Module																																																										
V	2016	Enclave	Body	Headlamp Control Module																																																										
V	2016	Enclave	Body	Radio																																																										
V	2016	Enclave	Body	Rear Audio Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
V	2016	Enclave	Body	Digital Radio Receiver Control Module																																																										
V	2016	Enclave	Body	Personal Audio Link Control Module																																																											
V	2016	Enclave	Body	Telematics Communication Interface Control Module																																																											
V	2016	Enclave	Body	HVAC Control Module																																																											
V	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																											
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																											
V	2016	Enclave	Body	Liftgate Control Module																																																											
V	2016	Enclave	Body	Seat Memory Control Module																																																											
V	2016	Enclave	Body	Front Seat Heating Control Module																																																											
V	2016	Enclave	Body	Right Side Object Detection Control Module																																																											
V	2016	Enclave	Body	Left Side Object Detection Control Module																																																											
V	2016	Enclave	Body	Remote Control Door Lock Receiver																																																											
V	2016	Enclave	Body	Parking Assist Control Module																																																											
V	2016	Enclave	Body	Frontview Camera Module																																																											
V	2016	Enclave	Body	Theft Deterrent Module																																																											
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																											
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																											
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module																																																											
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module																																																											
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module																																																											
X	2016	Envision	Chassis	Electronic Brake Control Module																																																											
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module																																																											
X	2016	Envision	Chassis	Power Steering Control Module																																																											
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module																																																											
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
X	2016	Envision	Body	Passenger Presence Module																																																											
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																											
X	2016	Envision	Body	Radio Controls																																																											
X	2016	Envision	Body	HVAC Controls																																																											
X	2016	Envision	Body	Video Processing Control Module																																																											
X	2016	Envision	Body	Headlamp Control Module																																																											
X	2016	Envision	Body	Radio																																																											
X	2016	Envision	Body	Amplifier																																																											
X	2016	Envision	Body	Human Machine Interface Control Module																																																											
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7																																																											
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10																																																											
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
X	2016	Envision	Body	Liftgate Control Module																																																											
X	2016	Envision	Body	Seat Memory Control Module - Driver																																																											
X	2016	Envision	Body	Keyless Entry Control Module																																																											
X	2016	Envision	Body	Right Side Object Detection Control Module																																																											
X	2016	Envision	Body	Left Side Object Detection Control Module																																																											
X	2016	Envision	Body	Parking Assist Control Module																																																											
X	2016	Envision	Body	Frontview Camera Module																																																											
X	2016	Envision	Body	Frontview Camera Module																																																											
X	2016	Envision	Body	Steering Column Lock Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
X	2016	Envision	Body	Power Supply Transformer																																																																
X	2016	Envision	Body	Long Range Radar Sensor Module																																																																

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																												
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																												
J	2013	Encore	Powertrain	Fuel Pump Control Module																																																													
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module																																																												
J	2013	Encore	Chassis	Electronic Brake Control Module																																																												
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2013	Encore	Chassis	Power Steering Control Module																																																												
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2013	Encore	Body	Body Control Module																																																												
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2013	Encore	Body	Passenger Presence Module																																																												
J	2013	Encore	Body	Instrument Cluster																																																												
J	2013	Encore	Body	Radio																																																												
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																												
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)																																																												
J	2013	Encore	Body	Seat Memory Control Module																																																												
J	2013	Encore	Body	Front Seat Heating Control Module																																																												
J	2013	Encore	Body	Parking Assist Control Module																																																												
J	2013	Encore	Body	Frontview Camera Module																																																												
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit																																																												
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																												
J	2014	Encore	Powertrain	Chassis Control Module																																																												
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module																																																												
J	2014	Encore	Chassis	Electronic Brake Control Module																																																												
J	2014	Encore	Chassis	Power Steering Control Module																																																												
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Encore	Body	Body Control Module																																																												
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Encore	Body	Passenger Presence Module																																																												
J	2014	Encore	Body	Instrument Cluster																																																												
J	2014	Encore	Body	Radio Other																																																												
J	2014	Encore	Body	Radio (UF7)																																																												
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																												
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)																																																												
J	2014	Encore	Body	Seat Memory Control Module																																																												
J	2014	Encore	Body	Front Seat Heating Control Module																																																												
J	2014	Encore	Body	Left Side Object Detection Control Module																																																												
J	2014	Encore	Body	Parking Assist Control Module																																																												
J	2014	Encore	Body	Frontview Camera Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																										
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2015	Encore	Powertrain	Chassis Control Module																																																										
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Encore	Chassis	Electronic Brake Control Module																																																										
J	2015	Encore	Chassis	Power Steering Control Module																																																										
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Encore	Body	Body Control Module																																																										
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Encore	Body	Passenger Presence Module																																																										
J	2015	Encore	Body	Instrument Cluster																																																										
J	2015	Encore	Body	Radio Other																																																										
J	2015	Encore	Body	Radio (UF7)																																																										
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																										
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)																																																										
J	2015	Encore	Body	Seat Memory Control Module																																																										
J	2015	Encore	Body	Front Seat Heating Control Module																																																										
J	2015	Encore	Body	Left Side Object Detection Control Module																																																										
J	2015	Encore	Body	Parking Assist Control Module																																																										
J	2015	Encore	Body	Frontview Camera Module																																																										
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																										
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																										
J	2016	Encore	Powertrain	Chassis Control Module																																																										
J	2016	Encore	Chassis	Electronic Brake Control Module																																																										
J	2016	Encore	Chassis	Power Steering Control Module																																																										
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Encore	Body	Body Control Module																																																										
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Encore	Body	Passenger Presence Module																																																										
J	2016	Encore	Body	Instrument Cluster																																																										
J	2016	Encore	Body	Radio																																																										
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																										
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)																																																										
J	2016	Encore	Body	Seat Memory Control Module																																																										
J	2016	Encore	Body	Front Seat Heating Control Module																																																										
J	2016	Encore	Body	Left Side Object Detection Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2016	Encore	Body	Parking Assist Control Module																																																									
J	2016	Encore	Body	Frontview Camera Module																																																									
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
R	2014	Enclave	Powertrain	Chassis Control Module																																																									
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																									
R	2014	Enclave	Chassis	Electronic Brake Control Module																																																									
R	2014	Enclave	Body	Body Control Module																																																									
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
R	2014	Enclave	Body	Passenger Presence Module																																																									
R	2014	Enclave	Body	Instrument Cluster																																																									
R	2014	Enclave	Body	Headlamp Control Module																																																									
R	2014	Enclave	Body	Radio																																																									
R	2014	Enclave	Body	Rear Audio Control Module																																																									
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																																									
R	2014	Enclave	Body	Personal Audio Link Control Module																																																									
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																									
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																									
R	2014	Enclave	Body	HVAC Control Module																																										V															
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																									
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																									
R	2014	Enclave	Body	Liftgate Control Module																																																									
R	2014	Enclave	Body	Seat Memory Control Module																																																									
R	2014	Enclave	Body	Front Seat Heating Control Module																																																									
R	2014	Enclave	Body	Right Side Object Detection Control Module																																																									
R	2014	Enclave	Body	Left Side Object Detection Control Module																																																									
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																																									
R	2014	Enclave	Body	Parking Assist Control Module																																																									
R	2014	Enclave	Body	Frontview Camera Module																																																									
R	2014	Enclave	Body	Theft Deterrent Module																																																									
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																									
R	2015	Enclave	Chassis	Electronic Brake Control Module																																																									
R	2015	Enclave	Body	Body Control Module																																																									
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
R	2015	Enclave	Body	Passenger Presence Module																																																									
R	2015	Enclave	Body	Instrument Cluster																																																									
R	2015	Enclave	Body	Head-Up Display Module																																																									
R	2015	Enclave	Body	Headlamp Control Module																																																									
R	2015	Enclave	Body	Radio																																																									
R	2015	Enclave	Body	Rear Audio Control Module																																																									
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																																									
R	2015	Enclave	Body	Personal Audio Link Control Module																																																									
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																									
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																									
R	2015	Enclave	Body	HVAC Control Module																																										V															
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																									
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																									
R	2015	Enclave	Body	Liftgate Control Module																																																									
R	2015	Enclave	Body	Seat Memory Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2015	Enclave	Body	Front Seat Heating Control Module																																																										
R	2015	Enclave	Body	Right Side Object Detection Control Module																																																											
R	2015	Enclave	Body	Left Side Object Detection Control Module																																																											
R	2015	Enclave	Body	Remote Control Door Lock Receiver																																																											
R	2015	Enclave	Body	Parking Assist Control Module																																																											
R	2015	Enclave	Body	Frontview Camera Module																																																											
R	2015	Enclave	Body	Theft Deterrent Module																																																											
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																											
R	2016	Enclave	Chassis	Electronic Brake Control Module																																																											
R	2016	Enclave	Body	Body Control Module																																																											
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2016	Enclave	Body	Passenger Presence Module																																																											
R	2016	Enclave	Body	Instrument Cluster																																																											
R	2016	Enclave	Body	Head-Up Display Module																																																											
R	2016	Enclave	Body	Headlamp Control Module																																																											
R	2016	Enclave	Body	Radio																																																											
R	2016	Enclave	Body	Rear Audio Control Module																																																											
R	2016	Enclave	Body	Digital Radio Receiver Control Module																																																											
R	2016	Enclave	Body	Personal Audio Link Control Module																																																											
R	2016	Enclave	Body	Telematics Communication Interface Control Module																																																											
R	2016	Enclave	Body	HVAC Control Module																																									V																	
R	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																											
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																											
R	2016	Enclave	Body	Liftgate Control Module																																																											
R	2016	Enclave	Body	Seat Memory Control Module																																																											
R	2016	Enclave	Body	Front Seat Heating Control Module																																																											
R	2016	Enclave	Body	Right Side Object Detection Control Module																																																											
R	2016	Enclave	Body	Left Side Object Detection Control Module																																																											
R	2016	Enclave	Body	Remote Control Door Lock Receiver																																																											
R	2016	Enclave	Body	Parking Assist Control Module																																																											
R	2016	Enclave	Body	Frontview Camera Module																																																											
R	2016	Enclave	Body	Theft Deterrent Module																																																											
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2014	Enclave	Powertrain	Chassis Control Module																																																											
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																											
V	2014	Enclave	Chassis	Electronic Brake Control Module																																																											
V	2014	Enclave	Body	Body Control Module																																																											
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
V	2014	Enclave	Body	Passenger Presence Module																																																											
V	2014	Enclave	Body	Instrument Cluster																																																											
V	2014	Enclave	Body	Headlamp Control Module																																																											
V	2014	Enclave	Body	Radio																																																											
V	2014	Enclave	Body	Rear Audio Control Module																																																											
V	2014	Enclave	Body	Digital Radio Receiver Control Module																																																											
V	2014	Enclave	Body	Personal Audio Link Control Module																																																											
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																											
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																											
V	2014	Enclave	Body	HVAC Control Module																																									V																	

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																									
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																									
V	2014	Enclave	Body	Liftgate Control Module																																																									
V	2014	Enclave	Body	Seat Memory Control Module																																																									
V	2014	Enclave	Body	Front Seat Heating Control Module																																																									
V	2014	Enclave	Body	Right Side Object Detection Control Module																																																									
V	2014	Enclave	Body	Left Side Object Detection Control Module																																																									
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																																									
V	2014	Enclave	Body	Parking Assist Control Module																																																									
V	2014	Enclave	Body	Frontview Camera Module																																																									
V	2014	Enclave	Body	Theft Deterrent Module																																																									
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																									
V	2015	Enclave	Chassis	Electronic Brake Control Module																																																									
V	2015	Enclave	Body	Body Control Module																																																									
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2015	Enclave	Body	Passenger Presence Module																																																									
V	2015	Enclave	Body	Instrument Cluster																																																									
V	2015	Enclave	Body	Head-Up Display Module																																																									
V	2015	Enclave	Body	Headlamp Control Module																																																									
V	2015	Enclave	Body	Radio																																																									
V	2015	Enclave	Body	Rear Audio Control Module																																																									
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																																									
V	2015	Enclave	Body	Personal Audio Link Control Module																																																									
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2015	Enclave	Body	HVAC Control Module																																										V															
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																									
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																									
V	2015	Enclave	Body	Liftgate Control Module																																																									
V	2015	Enclave	Body	Seat Memory Control Module																																																									
V	2015	Enclave	Body	Front Seat Heating Control Module																																																									
V	2015	Enclave	Body	Right Side Object Detection Control Module																																																									
V	2015	Enclave	Body	Left Side Object Detection Control Module																																																									
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																																									
V	2015	Enclave	Body	Parking Assist Control Module																																																									
V	2015	Enclave	Body	Frontview Camera Module																																																									
V	2015	Enclave	Body	Theft Deterrent Module																																																									
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																									
V	2016	Enclave	Chassis	Electronic Brake Control Module																																																									
V	2016	Enclave	Body	Body Control Module																																																									
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2016	Enclave	Body	Passenger Presence Module																																																									
V	2016	Enclave	Body	Instrument Cluster																																																									
V	2016	Enclave	Body	Head-Up Display Module																																																									
V	2016	Enclave	Body	Headlamp Control Module																																																									
V	2016	Enclave	Body	Radio																																																									
V	2016	Enclave	Body	Rear Audio Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
V	2016	Enclave	Body	Digital Radio Receiver Control Module																																																									
V	2016	Enclave	Body	Personal Audio Link Control Module																																																										
V	2016	Enclave	Body	Telematics Communication Interface Control Module																																																										
V	2016	Enclave	Body	HVAC Control Module																																									V																
V	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Enclave	Body	Liftgate Control Module																																																										
V	2016	Enclave	Body	Seat Memory Control Module																																																										
V	2016	Enclave	Body	Front Seat Heating Control Module																																																										
V	2016	Enclave	Body	Right Side Object Detection Control Module																																																										
V	2016	Enclave	Body	Left Side Object Detection Control Module																																																										
V	2016	Enclave	Body	Remote Control Door Lock Receiver																																																										
V	2016	Enclave	Body	Parking Assist Control Module																																																										
V	2016	Enclave	Body	Frontview Camera Module																																																										
V	2016	Enclave	Body	Theft Deterrent Module																																																										
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																										
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																										
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module																																																										
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module																																																										
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module																																																										
X	2016	Envision	Chassis	Electronic Brake Control Module																																																										
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module																																																										
X	2016	Envision	Chassis	Power Steering Control Module																																																										
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module																																																										
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
X	2016	Envision	Body	Passenger Presence Module																																																										
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																										
X	2016	Envision	Body	Radio Controls																																																										
X	2016	Envision	Body	HVAC Controls																																																										
X	2016	Envision	Body	Video Processing Control Module																																																										
X	2016	Envision	Body	Headlamp Control Module																																																										
X	2016	Envision	Body	Radio																																																										
X	2016	Envision	Body	Amplifier																																																										
X	2016	Envision	Body	Human Machine Interface Control Module																																																										
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7																																																										
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10																																																										
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
X	2016	Envision	Body	Liftgate Control Module																																																										
X	2016	Envision	Body	Seat Memory Control Module - Driver																																																										
X	2016	Envision	Body	Keyless Entry Control Module																																																										
X	2016	Envision	Body	Right Side Object Detection Control Module																																																										
X	2016	Envision	Body	Left Side Object Detection Control Module																																																										
X	2016	Envision	Body	Parking Assist Control Module																																																										
X	2016	Envision	Body	Frontview Camera Module																																																										
X	2016	Envision	Body	Frontview Camera Module																																																										
X	2016	Envision	Body	Steering Column Lock Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
X	2016	Envision	Body	Power Supply Transformer																																																												
X	2016	Envision	Body	Long Range Radar Sensor Module																																																													

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																								
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																								
J	2013	Encore	Powertrain	Fuel Pump Control Module																																																								
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module																																												V												
J	2013	Encore	Chassis	Electronic Brake Control Module																																																								
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Encore	Chassis	Power Steering Control Module																																																								
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2013	Encore	Body	Body Control Module																																																								
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2013	Encore	Body	Passenger Presence Module																																																								
J	2013	Encore	Body	Instrument Cluster																																																								
J	2013	Encore	Body	Radio																																																								
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																								
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)																																																								
J	2013	Encore	Body	Seat Memory Control Module																																																								
J	2013	Encore	Body	Front Seat Heating Control Module																																																								
J	2013	Encore	Body	Parking Assist Control Module																																																								
J	2013	Encore	Body	Frontview Camera Module																																																								
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit																																																								
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																								
J	2014	Encore	Powertrain	Chassis Control Module																																																								
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module																																												V												
J	2014	Encore	Chassis	Electronic Brake Control Module																																																								
J	2014	Encore	Chassis	Power Steering Control Module																																																								
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2014	Encore	Body	Body Control Module																																																								
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2014	Encore	Body	Passenger Presence Module																																																								
J	2014	Encore	Body	Instrument Cluster																																																								
J	2014	Encore	Body	Radio Other																																																								
J	2014	Encore	Body	Radio (UF7)																																																								
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																								
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)																																																								
J	2014	Encore	Body	Seat Memory Control Module																																																								
J	2014	Encore	Body	Front Seat Heating Control Module																																																								
J	2014	Encore	Body	Left Side Object Detection Control Module																																																								
J	2014	Encore	Body	Parking Assist Control Module																																																								
J	2014	Encore	Body	Frontview Camera Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																								
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																								
J	2015	Encore	Powertrain	Chassis Control Module																																																								
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module																																												V												
J	2015	Encore	Chassis	Electronic Brake Control Module																																																								
J	2015	Encore	Chassis	Power Steering Control Module																																																								
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2015	Encore	Body	Body Control Module																																																								
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Encore	Body	Passenger Presence Module																																																								
J	2015	Encore	Body	Instrument Cluster																																																								
J	2015	Encore	Body	Radio Other																																																								
J	2015	Encore	Body	Radio (UF7)																																																								
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																								
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																								
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)																																																								
J	2015	Encore	Body	Seat Memory Control Module																																																								
J	2015	Encore	Body	Front Seat Heating Control Module																																																								
J	2015	Encore	Body	Left Side Object Detection Control Module																																																								
J	2015	Encore	Body	Parking Assist Control Module																																																								
J	2015	Encore	Body	Frontview Camera Module																																																								
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																								
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																								
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																								
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																																								
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																																								
J	2016	Encore	Powertrain	Chassis Control Module																																																								
J	2016	Encore	Chassis	Electronic Brake Control Module																																																								
J	2016	Encore	Chassis	Power Steering Control Module																																																								
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2016	Encore	Body	Body Control Module																																																								
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2016	Encore	Body	Passenger Presence Module																																																								
J	2016	Encore	Body	Instrument Cluster																																																								
J	2016	Encore	Body	Radio																																																								
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																																								
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																																								
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)																																																								
J	2016	Encore	Body	Seat Memory Control Module																																																								
J	2016	Encore	Body	Front Seat Heating Control Module																																																								
J	2016	Encore	Body	Left Side Object Detection Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2016	Encore	Body	Parking Assist Control Module																																																								
J	2016	Encore	Body	Frontview Camera Module																																																								
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2014	Enclave	Powertrain	Chassis Control Module																																																								
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																								
R	2014	Enclave	Chassis	Electronic Brake Control Module																																																								
R	2014	Enclave	Body	Body Control Module																																																								
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2014	Enclave	Body	Passenger Presence Module																																																								
R	2014	Enclave	Body	Instrument Cluster																																																								
R	2014	Enclave	Body	Headlamp Control Module																																																								
R	2014	Enclave	Body	Radio																																																								
R	2014	Enclave	Body	Rear Audio Control Module																																																								
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																																								
R	2014	Enclave	Body	Personal Audio Link Control Module																																																								
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2014	Enclave	Body	HVAC Control Module																																																								
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																								
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																								
R	2014	Enclave	Body	Liftgate Control Module																																																								
R	2014	Enclave	Body	Seat Memory Control Module																																																								
R	2014	Enclave	Body	Front Seat Heating Control Module																																																								
R	2014	Enclave	Body	Right Side Object Detection Control Module																																																								
R	2014	Enclave	Body	Left Side Object Detection Control Module																																																								
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																																								
R	2014	Enclave	Body	Parking Assist Control Module																																																								
R	2014	Enclave	Body	Frontview Camera Module																																																								
R	2014	Enclave	Body	Theft Deterrent Module																																																								
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																								
R	2015	Enclave	Chassis	Electronic Brake Control Module																																																								
R	2015	Enclave	Body	Body Control Module																																																								
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2015	Enclave	Body	Passenger Presence Module																																																								
R	2015	Enclave	Body	Instrument Cluster																																																								
R	2015	Enclave	Body	Head-Up Display Module																																																								
R	2015	Enclave	Body	Headlamp Control Module																																																								
R	2015	Enclave	Body	Radio																																																								
R	2015	Enclave	Body	Rear Audio Control Module																																																								
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																																								
R	2015	Enclave	Body	Personal Audio Link Control Module																																																								
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2015	Enclave	Body	HVAC Control Module																																																								
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																								
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																								
R	2015	Enclave	Body	Liftgate Control Module																																																								
R	2015	Enclave	Body	Seat Memory Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2015	Enclave	Body	Front Seat Heating Control Module																																																										
R	2015	Enclave	Body	Right Side Object Detection Control Module																																																										
R	2015	Enclave	Body	Left Side Object Detection Control Module																																																										
R	2015	Enclave	Body	Remote Control Door Lock Receiver																																																										
R	2015	Enclave	Body	Parking Assist Control Module																																																										
R	2015	Enclave	Body	Frontview Camera Module																																																										
R	2015	Enclave	Body	Theft Deterrent Module																																																										
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
R	2016	Enclave	Chassis	Electronic Brake Control Module																																																										
R	2016	Enclave	Body	Body Control Module																																																										
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Enclave	Body	Passenger Presence Module																																																										
R	2016	Enclave	Body	Instrument Cluster																																																										
R	2016	Enclave	Body	Head-Up Display Module																																																										
R	2016	Enclave	Body	Headlamp Control Module																																																										
R	2016	Enclave	Body	Radio																																																										
R	2016	Enclave	Body	Rear Audio Control Module																																																										
R	2016	Enclave	Body	Digital Radio Receiver Control Module																																																										
R	2016	Enclave	Body	Personal Audio Link Control Module																																																V										
R	2016	Enclave	Body	Telematics Communication Interface Control Module																																																										
R	2016	Enclave	Body	HVAC Control Module																																																										
R	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Enclave	Body	Liftgate Control Module																																																										
R	2016	Enclave	Body	Seat Memory Control Module																																																										
R	2016	Enclave	Body	Front Seat Heating Control Module																																																										
R	2016	Enclave	Body	Right Side Object Detection Control Module																																																										
R	2016	Enclave	Body	Left Side Object Detection Control Module																																																										
R	2016	Enclave	Body	Remote Control Door Lock Receiver																																																										
R	2016	Enclave	Body	Parking Assist Control Module																																																										
R	2016	Enclave	Body	Frontview Camera Module																																																										
R	2016	Enclave	Body	Theft Deterrent Module																																																										
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2014	Enclave	Powertrain	Chassis Control Module																																																										
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																																										
V	2014	Enclave	Chassis	Electronic Brake Control Module																																																V										
V	2014	Enclave	Body	Body Control Module																																																										
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2014	Enclave	Body	Passenger Presence Module																																																										
V	2014	Enclave	Body	Instrument Cluster																																																										
V	2014	Enclave	Body	Headlamp Control Module																																																										
V	2014	Enclave	Body	Radio																																																										
V	2014	Enclave	Body	Rear Audio Control Module																																																										
V	2014	Enclave	Body	Digital Radio Receiver Control Module																																																										
V	2014	Enclave	Body	Personal Audio Link Control Module																																																V										
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2014	Enclave	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																																																											
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																																											
V	2014	Enclave	Body	Liftgate Control Module																																																											
V	2014	Enclave	Body	Seat Memory Control Module																																																											
V	2014	Enclave	Body	Front Seat Heating Control Module																																																											
V	2014	Enclave	Body	Right Side Object Detection Control Module																																																											
V	2014	Enclave	Body	Left Side Object Detection Control Module																																																											
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																																											
V	2014	Enclave	Body	Parking Assist Control Module																																																											
V	2014	Enclave	Body	Frontview Camera Module																																																											
V	2014	Enclave	Body	Theft Deterrent Module																																																											
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																																											
V	2015	Enclave	Chassis	Electronic Brake Control Module																																																V											
V	2015	Enclave	Body	Body Control Module																																																											
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
V	2015	Enclave	Body	Passenger Presence Module																																																											
V	2015	Enclave	Body	Instrument Cluster																																																											
V	2015	Enclave	Body	Head-Up Display Module																																																											
V	2015	Enclave	Body	Headlamp Control Module																																																											
V	2015	Enclave	Body	Radio																																																											
V	2015	Enclave	Body	Rear Audio Control Module																																																											
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																																											
V	2015	Enclave	Body	Personal Audio Link Control Module																																																	V											
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																																											
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																																											
V	2015	Enclave	Body	HVAC Control Module																																																											
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																																																											
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																																											
V	2015	Enclave	Body	Liftgate Control Module																																																											
V	2015	Enclave	Body	Seat Memory Control Module																																																											
V	2015	Enclave	Body	Front Seat Heating Control Module																																																											
V	2015	Enclave	Body	Right Side Object Detection Control Module																																																											
V	2015	Enclave	Body	Left Side Object Detection Control Module																																																											
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																																											
V	2015	Enclave	Body	Parking Assist Control Module																																																											
V	2015	Enclave	Body	Frontview Camera Module																																																											
V	2015	Enclave	Body	Theft Deterrent Module																																																											
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																																											
V	2016	Enclave	Chassis	Electronic Brake Control Module																																																V											
V	2016	Enclave	Body	Body Control Module																																																											
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
V	2016	Enclave	Body	Passenger Presence Module																																																											
V	2016	Enclave	Body	Instrument Cluster																																																											
V	2016	Enclave	Body	Head-Up Display Module																																																											
V	2016	Enclave	Body	Headlamp Control Module																																																											
V	2016	Enclave	Body	Radio																																																											
V	2016	Enclave	Body	Rear Audio Control Module																																																											

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
V	2016	Enclave	Body	Digital Radio Receiver Control Module																																																									
V	2016	Enclave	Body	Personal Audio Link Control Module																																															V										
V	2016	Enclave	Body	Telematics Communication Interface Control Module																																																									
V	2016	Enclave	Body	HVAC Control Module																																																									
V	2016	Enclave	Body	Driver Door Switch Panel Control Module																																																									
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																																									
V	2016	Enclave	Body	Liftgate Control Module																																																									
V	2016	Enclave	Body	Seat Memory Control Module																																																									
V	2016	Enclave	Body	Front Seat Heating Control Module																																																									
V	2016	Enclave	Body	Right Side Object Detection Control Module																																																									
V	2016	Enclave	Body	Left Side Object Detection Control Module																																																									
V	2016	Enclave	Body	Remote Control Door Lock Receiver																																																									
V	2016	Enclave	Body	Parking Assist Control Module																																																									
V	2016	Enclave	Body	Frontview Camera Module																																																									
V	2016	Enclave	Body	Theft Deterrent Module																																																									
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																																									
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																																									
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module																																																									
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module																																																									
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module																																												V													
X	2016	Envision	Chassis	Electronic Brake Control Module																																																									
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module																																																									
X	2016	Envision	Chassis	Power Steering Control Module																																																									
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module																																																									
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
X	2016	Envision	Body	Passenger Presence Module																																																									
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																									
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																																									
X	2016	Envision	Body	Radio Controls																																																									
X	2016	Envision	Body	HVAC Controls																																																									
X	2016	Envision	Body	Video Processing Control Module																																																									
X	2016	Envision	Body	Headlamp Control Module																																																									
X	2016	Envision	Body	Radio																																																									
X	2016	Envision	Body	Amplifier																																																									
X	2016	Envision	Body	Human Machine Interface Control Module																																																									
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7																																																									
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10																																																									
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)																																																									
X	2016	Envision	Body	Liftgate Control Module																																															V										
X	2016	Envision	Body	Seat Memory Control Module - Driver																																																									
X	2016	Envision	Body	Keyless Entry Control Module																																																									
X	2016	Envision	Body	Right Side Object Detection Control Module																																																									
X	2016	Envision	Body	Left Side Object Detection Control Module																																																									
X	2016	Envision	Body	Parking Assist Control Module																																																									
X	2016	Envision	Body	Frontview Camera Module																																																									
X	2016	Envision	Body	Frontview Camera Module																																																									
X	2016	Envision	Body	Steering Column Lock Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
X	2016	Envision	Body	Power Supply Transformer																																																										
X	2016	Envision	Body	Long Range Radar Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
J	2013	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
J	2013	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																								
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								
J	2013	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								
J	2013	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																								
J	2013	Encore	Powertrain	Fuel Pump Control Module																																								
J	2013	Encore	Powertrain	Rear Differential Clutch Control Module																																								
J	2013	Encore	Chassis	Electronic Brake Control Module																																								
J	2013	Encore	Chassis	Multi-Axis Acceleration Sensor Module																																								
J	2013	Encore	Chassis	Power Steering Control Module																																								
J	2013	Encore	Chassis	Steering Wheel Angle Sensor Module																																								
J	2013	Encore	Body	Body Control Module																																								
J	2013	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
J	2013	Encore	Body	Passenger Presence Module																																								
J	2013	Encore	Body	Instrument Cluster																																								
J	2013	Encore	Body	Radio																																								
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 9																																								
J	2013	Encore	Body	Telematics Communication Interface Control Module Version 10																																								
J	2013	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																								
J	2013	Encore	Body	HVAC Control Module Manual Single (C67)																																								
J	2013	Encore	Body	Seat Memory Control Module																																								
J	2013	Encore	Body	Front Seat Heating Control Module																																								
J	2013	Encore	Body	Parking Assist Control Module																																								
J	2013	Encore	Body	Frontview Camera Module																																								
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																								
J	2014	Encore	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																								
J	2014	Encore	Powertrain	(8) 1.4L LUJ Transmission Control Unit																																								
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								
J	2014	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								
J	2014	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																								
J	2014	Encore	Powertrain	Chassis Control Module																																								
J	2014	Encore	Powertrain	Rear Differential Clutch Control Module																																								
J	2014	Encore	Chassis	Electronic Brake Control Module																																								
J	2014	Encore	Chassis	Power Steering Control Module																																								
J	2014	Encore	Chassis	Steering Wheel Angle Sensor Module																																								
J	2014	Encore	Body	Body Control Module																																								
J	2014	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
J	2014	Encore	Body	Passenger Presence Module																																								
J	2014	Encore	Body	Instrument Cluster																																								
J	2014	Encore	Body	Radio Other																																								
J	2014	Encore	Body	Radio (UF7)																																								
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 9																																								
J	2014	Encore	Body	Telematics Communication Interface Control Module Version 10																																								
J	2014	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																								
J	2014	Encore	Body	HVAC Control Module Manual Single (C67)																																								
J	2014	Encore	Body	Seat Memory Control Module																																								
J	2014	Encore	Body	Front Seat Heating Control Module																																								
J	2014	Encore	Body	Left Side Object Detection Control Module																																								
J	2014	Encore	Body	Parking Assist Control Module																																								
J	2014	Encore	Body	Frontview Camera Module																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
J	2015	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
J	2015	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																								
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								
J	2015	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								
J	2015	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																								
J	2015	Encore	Powertrain	Chassis Control Module																																								
J	2015	Encore	Powertrain	Rear Differential Clutch Control Module																																								
J	2015	Encore	Chassis	Electronic Brake Control Module																																								
J	2015	Encore	Chassis	Power Steering Control Module																																								
J	2015	Encore	Chassis	Steering Wheel Angle Sensor Module																																								
J	2015	Encore	Body	Body Control Module																																								
J	2015	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
J	2015	Encore	Body	Passenger Presence Module																																								
J	2015	Encore	Body	Instrument Cluster																																								
J	2015	Encore	Body	Radio Other																																								
J	2015	Encore	Body	Radio (UF7)																																								
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																								
J	2015	Encore	Body	Telematics Communication Interface Control Module Version 10																																								
J	2015	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																								
J	2015	Encore	Body	HVAC Control Module Manual Single (C67)																																								
J	2015	Encore	Body	Seat Memory Control Module																																								
J	2015	Encore	Body	Front Seat Heating Control Module																																								
J	2015	Encore	Body	Left Side Object Detection Control Module																																								
J	2015	Encore	Body	Parking Assist Control Module																																								
J	2015	Encore	Body	Frontview Camera Module																																								
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																								
J	2016	Encore	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																								
J	2016	Encore	Powertrain	(M) 1.4L LE2 Transmission Control Module																																								
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
J	2016	Encore	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
J	2016	Encore	Powertrain	1.4L LUJ Transmission Control Unit																																								
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								
J	2016	Encore	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								
J	2016	Encore	Powertrain	(B) 1.4L LUV Transmission Control Unit																																								
J	2016	Encore	Powertrain	Chassis Control Module																																								
J	2016	Encore	Chassis	Electronic Brake Control Module																																								
J	2016	Encore	Chassis	Power Steering Control Module																																								
J	2016	Encore	Chassis	Steering Wheel Angle Sensor Module																																								
J	2016	Encore	Body	Body Control Module																																								
J	2016	Encore	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
J	2016	Encore	Body	Passenger Presence Module																																								
J	2016	Encore	Body	Instrument Cluster																																								
J	2016	Encore	Body	Radio																																								
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 9.7																																								
J	2016	Encore	Body	Telematics Communication Interface Control Module Version 10																																								
J	2016	Encore	Body	HVAC Control Module Auto Dual (CJ2)																																								
J	2016	Encore	Body	HVAC Control Module Manual Single (C67)																																								
J	2016	Encore	Body	Seat Memory Control Module																																								
J	2016	Encore	Body	Front Seat Heating Control Module																																								
J	2016	Encore	Body	Left Side Object Detection Control Module																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data
J	2016	Encore	Body	Parking Assist Control Module																																								
J	2016	Encore	Body	Frontview Camera Module																																								
R	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																								
R	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
R	2014	Enclave	Powertrain	Chassis Control Module																																								
R	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																								
R	2014	Enclave	Chassis	Electronic Brake Control Module																																								
R	2014	Enclave	Body	Body Control Module																																								
R	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
R	2014	Enclave	Body	Passenger Presence Module																																								
R	2014	Enclave	Body	Instrument Cluster																																								
R	2014	Enclave	Body	Headlamp Control Module																																								
R	2014	Enclave	Body	Radio																																								
R	2014	Enclave	Body	Rear Audio Control Module																																								
R	2014	Enclave	Body	Digital Radio Receiver Control Module																																								
R	2014	Enclave	Body	Personal Audio Link Control Module																																								
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																								
R	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																								
R	2014	Enclave	Body	HVAC Control Module																																								
R	2014	Enclave	Body	Driver Door Switch Panel Control Module																																								
R	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																								
R	2014	Enclave	Body	Liftgate Control Module																																								
R	2014	Enclave	Body	Seat Memory Control Module																																								
R	2014	Enclave	Body	Front Seat Heating Control Module																																								
R	2014	Enclave	Body	Right Side Object Detection Control Module																																								
R	2014	Enclave	Body	Left Side Object Detection Control Module																																								
R	2014	Enclave	Body	Remote Control Door Lock Receiver																																								
R	2014	Enclave	Body	Parking Assist Control Module																																								
R	2014	Enclave	Body	Frontview Camera Module																																								
R	2014	Enclave	Body	Theft Deterrent Module																																								
R	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																								
R	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
R	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																								
R	2015	Enclave	Chassis	Electronic Brake Control Module																																								
R	2015	Enclave	Body	Body Control Module																																								
R	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
R	2015	Enclave	Body	Passenger Presence Module																																								
R	2015	Enclave	Body	Instrument Cluster																																								
R	2015	Enclave	Body	Head-Up Display Module																																								
R	2015	Enclave	Body	Headlamp Control Module																																								
R	2015	Enclave	Body	Radio																																								
R	2015	Enclave	Body	Rear Audio Control Module																																								
R	2015	Enclave	Body	Digital Radio Receiver Control Module																																								
R	2015	Enclave	Body	Personal Audio Link Control Module																																								
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																								
R	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																								
R	2015	Enclave	Body	HVAC Control Module																																								
R	2015	Enclave	Body	Driver Door Switch Panel Control Module																																								
R	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																								
R	2015	Enclave	Body	Liftgate Control Module																																								
R	2015	Enclave	Body	Seat Memory Control Module																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data
R	2015	Enclave	Body	Front Seat Heating Control Module																																								
R	2015	Enclave	Body	Right Side Object Detection Control Module																																								
R	2015	Enclave	Body	Left Side Object Detection Control Module																																								
R	2015	Enclave	Body	Remote Control Door Lock Receiver																																								
R	2015	Enclave	Body	Parking Assist Control Module																																								
R	2015	Enclave	Body	Frontview Camera Module																																								
R	2015	Enclave	Body	Theft Deterrent Module																																								
R	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																								
R	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
R	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																								
R	2016	Enclave	Chassis	Electronic Brake Control Module																																								
R	2016	Enclave	Body	Body Control Module																																								
R	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
R	2016	Enclave	Body	Passenger Presence Module																																								
R	2016	Enclave	Body	Instrument Cluster																																								
R	2016	Enclave	Body	Head-Up Display Module																																								
R	2016	Enclave	Body	Headlamp Control Module																																								
R	2016	Enclave	Body	Radio																																								
R	2016	Enclave	Body	Rear Audio Control Module																																								
R	2016	Enclave	Body	Digital Radio Receiver Control Module																																								
R	2016	Enclave	Body	Personal Audio Link Control Module																																								
R	2016	Enclave	Body	Telematics Communication Interface Control Module																																								
R	2016	Enclave	Body	HVAC Control Module																																								
R	2016	Enclave	Body	Driver Door Switch Panel Control Module																																								
R	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																								
R	2016	Enclave	Body	Liftgate Control Module																																								
R	2016	Enclave	Body	Seat Memory Control Module																																								
R	2016	Enclave	Body	Front Seat Heating Control Module																																								
R	2016	Enclave	Body	Right Side Object Detection Control Module																																								
R	2016	Enclave	Body	Left Side Object Detection Control Module																																								
R	2016	Enclave	Body	Remote Control Door Lock Receiver																																								
R	2016	Enclave	Body	Parking Assist Control Module																																								
R	2016	Enclave	Body	Frontview Camera Module																																								
R	2016	Enclave	Body	Theft Deterrent Module																																								
V	2014	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																								
V	2014	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
V	2014	Enclave	Powertrain	Chassis Control Module																																								
V	2014	Enclave	Powertrain	Rear Differential Clutch Control Module																																								
V	2014	Enclave	Chassis	Electronic Brake Control Module																																								
V	2014	Enclave	Body	Body Control Module																																								
V	2014	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
V	2014	Enclave	Body	Passenger Presence Module																																								
V	2014	Enclave	Body	Instrument Cluster																																								
V	2014	Enclave	Body	Headlamp Control Module																																								
V	2014	Enclave	Body	Radio																																								
V	2014	Enclave	Body	Rear Audio Control Module																																								
V	2014	Enclave	Body	Digital Radio Receiver Control Module																																								
V	2014	Enclave	Body	Personal Audio Link Control Module																																								
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 9																																								
V	2014	Enclave	Body	Telematics Communication Interface Control Module Version 10																																								
V	2014	Enclave	Body	HVAC Control Module																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data
V	2014	Enclave	Body	Driver Door Switch Panel Control Module																																								
V	2014	Enclave	Body	Passenger Door Switch Panel Control Module																																								
V	2014	Enclave	Body	Liftgate Control Module																																								
V	2014	Enclave	Body	Seat Memory Control Module																																								
V	2014	Enclave	Body	Front Seat Heating Control Module																																								
V	2014	Enclave	Body	Right Side Object Detection Control Module																																								
V	2014	Enclave	Body	Left Side Object Detection Control Module																																								
V	2014	Enclave	Body	Remote Control Door Lock Receiver																																								
V	2014	Enclave	Body	Parking Assist Control Module																																								
V	2014	Enclave	Body	Frontview Camera Module																																								
V	2014	Enclave	Body	Theft Deterrent Module																																								
V	2015	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																								
V	2015	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
V	2015	Enclave	Powertrain	Rear Differential Clutch Control Module																																								
V	2015	Enclave	Chassis	Electronic Brake Control Module																																								
V	2015	Enclave	Body	Body Control Module																																								
V	2015	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
V	2015	Enclave	Body	Passenger Presence Module																																								
V	2015	Enclave	Body	Instrument Cluster																																								
V	2015	Enclave	Body	Head-Up Display Module																																								
V	2015	Enclave	Body	Headlamp Control Module																																								
V	2015	Enclave	Body	Radio																																								
V	2015	Enclave	Body	Rear Audio Control Module																																								
V	2015	Enclave	Body	Digital Radio Receiver Control Module																																								
V	2015	Enclave	Body	Personal Audio Link Control Module																																								
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 9																																								
V	2015	Enclave	Body	Telematics Communication Interface Control Module Version 10																																								
V	2015	Enclave	Body	HVAC Control Module																																								
V	2015	Enclave	Body	Driver Door Switch Panel Control Module																																								
V	2015	Enclave	Body	Passenger Door Switch Panel Control Module																																								
V	2015	Enclave	Body	Liftgate Control Module																																								
V	2015	Enclave	Body	Seat Memory Control Module																																								
V	2015	Enclave	Body	Front Seat Heating Control Module																																								
V	2015	Enclave	Body	Right Side Object Detection Control Module																																								
V	2015	Enclave	Body	Left Side Object Detection Control Module																																								
V	2015	Enclave	Body	Remote Control Door Lock Receiver																																								
V	2015	Enclave	Body	Parking Assist Control Module																																								
V	2015	Enclave	Body	Frontview Camera Module																																								
V	2015	Enclave	Body	Theft Deterrent Module																																								
V	2016	Enclave	Powertrain	(D) 3.6L LLT Engine Control Module																																								
V	2016	Enclave	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
V	2016	Enclave	Powertrain	Rear Differential Clutch Control Module																																								
V	2016	Enclave	Chassis	Electronic Brake Control Module																																								
V	2016	Enclave	Body	Body Control Module																																								
V	2016	Enclave	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
V	2016	Enclave	Body	Passenger Presence Module																																								
V	2016	Enclave	Body	Instrument Cluster																																								
V	2016	Enclave	Body	Head-Up Display Module																																								
V	2016	Enclave	Body	Headlamp Control Module																																								
V	2016	Enclave	Body	Radio																																								
V	2016	Enclave	Body	Rear Audio Control Module																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data
V	2016	Enclave	Body	Digital Radio Receiver Control Module																																								
V	2016	Enclave	Body	Personal Audio Link Control Module																																								
V	2016	Enclave	Body	Telematics Communication Interface Control Module																																								
V	2016	Enclave	Body	HVAC Control Module																																								
V	2016	Enclave	Body	Driver Door Switch Panel Control Module																																								
V	2016	Enclave	Body	Passenger Door Switch Panel Control Module																																								
V	2016	Enclave	Body	Liftgate Control Module																																								
V	2016	Enclave	Body	Seat Memory Control Module																																								
V	2016	Enclave	Body	Front Seat Heating Control Module																																								
V	2016	Enclave	Body	Right Side Object Detection Control Module																																								
V	2016	Enclave	Body	Left Side Object Detection Control Module																																								
V	2016	Enclave	Body	Remote Control Door Lock Receiver																																								
V	2016	Enclave	Body	Parking Assist Control Module																																								
V	2016	Enclave	Body	Frontview Camera Module																																								
V	2016	Enclave	Body	Theft Deterrent Module																																								
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Automatic Transmission																																								
X	2016	Envision	Powertrain	(X) 2.0L LTG Engine Control Module Manual Transmission																																								
X	2016	Envision	Powertrain	(X) 2.0L LTG Transmission Control Module																																								
X	2016	Envision	Powertrain	(A) 2.5L LCV Engine Control Module																																								
X	2016	Envision	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
X	2016	Envision	Powertrain	Rear Differential Clutch Control Module																																								
X	2016	Envision	Chassis	Electronic Brake Control Module																																								
X	2016	Envision	Chassis	Multi-Axis Acceleration Sensor Module																																								
X	2016	Envision	Chassis	Power Steering Control Module																																								
X	2016	Envision	Chassis	Steering Wheel Angle Sensor Module																																								
X	2016	Envision	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																								
X	2016	Envision	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																								
X	2016	Envision	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
X	2016	Envision	Body	Passenger Presence Module																																								
X	2016	Envision	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																								
X	2016	Envision	Body	Instrument Cluster Enhanced Multi-Color Driver Information Center (UHS)																																								
X	2016	Envision	Body	Radio Controls																																								
X	2016	Envision	Body	HVAC Controls																																								
X	2016	Envision	Body	Video Processing Control Module																																								
X	2016	Envision	Body	Headlamp Control Module																																								
X	2016	Envision	Body	Radio																																								
X	2016	Envision	Body	Amplifier																																								
X	2016	Envision	Body	Human Machine Interface Control Module																																								
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 9.7																																								
X	2016	Envision	Body	Telematics Communication Interface Control Module Version 10																																								
X	2016	Envision	Body	HVAC Auto Control Dual Zone (CJ2)																																								
X	2016	Envision	Body	HVAC Auto Control Tri Zone (CJ4)																																								
X	2016	Envision	Body	Liftgate Control Module																																								
X	2016	Envision	Body	Seat Memory Control Module - Driver																																								
X	2016	Envision	Body	Keyless Entry Control Module																																								
X	2016	Envision	Body	Right Side Object Detection Control Module																																								
X	2016	Envision	Body	Left Side Object Detection Control Module																																								
X	2016	Envision	Body	Parking Assist Control Module																																								
X	2016	Envision	Body	Frontview Camera Module																																								
X	2016	Envision	Body	Frontview Camera Module																																								
X	2016	Envision	Body	Steering Column Lock Control Module																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data
X	2016	Envision	Body	Power Supply Transformer																																								
X	2016	Envision	Body	Long Range Radar Sensor Module																																								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V	V		V	V							V													V																
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V											V	V																									
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW	V	V																		V																																					
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																				
C	2004	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																				
C	2004	ALL	Chassis	ESC	V	V																		V	V																																				
C	2004	ALL	Chassis	Rear Wheel Steering	V	V																		V	V																																				
C	2004	ALL	Chassis	Tire Pressure Monitor	V	V																																																						
C	2004	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
C	2004	ALL	Chassis	VSES	V	V																		V	V																																			
C	2004	ALL	Body	Amplifier (Bose)	V	V																			V																																			
C	2004	ALL	Body	Body Control Module	V	V																		V	V																																			
C	2004	ALL	Body	CD Changer	V																																																						
C	2004	ALL	Body	Chime	V	V																		V	V																																			
C	2004	ALL	Body	Driver Door Module	V	V																		V	V																																			
C	2004	ALL	Body	Driver Seat Module	V	V																		V	V																																			
C	2004	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																			
C	2004	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
C	2004	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2004	ALL	Body	OnStar	V	V																		V	V																																			
C	2004	ALL	Body	Passenger Door Module	V	V																		V	V																																			
C	2004	ALL	Body	Passenger Presence System																																																							
C	2004	ALL	Body	Base Radio	V	V																			V																																			
C	2004	ALL	Body	Uplevel Radio	V	V																			V																																			
C	2004	ALL	Body	Navigation Radio	V	V																		V																																			
C	2004	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
C	2004	ALL	Body	Rear HVAC	V	V																			V																																			
C	2004	ALL	Body	Rear Seat Audio	V	V																			V																																			
C	2004	ALL	Body	Rear Seat Entertainment	V																				V																																			
C	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V	V		V	V							V													V															
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V											V	V																									
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum	V	V																		V	V																																				
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk	V	V																		V																																				
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																				
C	2005	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																				
C	2005	ALL	Chassis	ESC	V	V																		V	V																																				
C	2005	ALL	Chassis	Rear Wheel Steering	V	V																		V	V																																				
C	2005	ALL	Chassis	Tire Pressure Monitor	V	V																																																						
C	2005	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
C	2005	ALL	Chassis	VSES	V	V																		V	V																																			
C	2005	ALL	Body	Amplifier (Bose)	V	V																			V																																			
C	2005	ALL	Body	Body Control Module	V	V																		V	V																																			
C	2005	ALL	Body	CD Changer	V																																																						
C	2005	ALL	Body	Chime	V	V																		V	V																																			
C	2005	ALL	Body	Disc Player and Video Display	V																				V																																			
C	2005	ALL	Body	Driver Door Module	V	V																		V	V																																			
C	2005	ALL	Body	Driver Seat Module	V	V																		V	V																																			
C	2005	ALL	Body	Generator Battery Control Module	V	V																		V	V																																			
C	2005	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																				
C	2005	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
C	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2005	ALL	Body	Passenger Door Module	V	V																		V	V																																			
C	2005	ALL	Body	Passenger Presence System																																																								
C	2005	ALL	Body	Base Radio	V	V																			V																																			
C	2005	ALL	Body	Uplevel Radio	V	V																			V																																			
C	2005	ALL	Body	Navigation Radio	V	V																		V																																			
C	2005	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
C	2005	ALL	Body	Rear HVAC	V	V																			V																																			
C	2005	ALL	Body	Rear Seat Audio	V	V																			V																																			
C	2005	ALL	Body	Remote Function Actuation	V	V																																																						
C	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
C	2005	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V											V	V																							
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum	V	V																		V	V																																			
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk	V	V																		V																																			
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																			
C	2006	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																			
C	2006	ALL	Chassis	ESC	V	V																		V	V																																			
C	2006	ALL	Chassis	Tire Pressure Monitor	V	V																																																					
C	2006	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
C	2006	ALL	Chassis	VSES	V	V																		V	V																																			
C	2006	ALL	Body	Amplifier (Bose)	V	V																			V																																			
C	2006	ALL	Body	Body Control Module	V	V																		V	V																																			
C	2006	ALL	Body	CD Changer	V																																																						
C	2006	ALL	Body	Chime	V	V																		V	V																																			
C	2006	ALL	Body	Disc Player and Video Display	V																				V																																			
C	2006	ALL	Body	Driver Door Module	V	V																		V	V																																			
C	2006	ALL	Body	Driver Seat Module	V	V																		V	V																																			
C	2006	ALL	Body	Generator Battery Control Module	V	V																		V	V																																			
C	2006	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																			
C	2006	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
C	2006	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2006	ALL	Body	Passenger Door Module	V	V																		V	V																																			
C	2006	ALL	Body	Passenger Presence System																																																							
C	2006	ALL	Body	Base Radio	V	V																			V																																			
C	2006	ALL	Body	Uplevel Radio	V	V																			V																																			
C	2006	ALL	Body	Navigation Radio	V	V																		V																																			
C	2006	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
C	2006	ALL	Body	Rear HVAC	V	V																			V																																			
C	2006	ALL	Body	Rear Seat Audio	V	V																			V																																			
C	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
C	2006	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V																			V																
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V											V	V	V																							
C	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2007	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2007	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2007	ALL	Body	Assist Step Controller	V	V																		V	V																																			
C	2007	ALL	Body	Body Control Module	V	V																		V	V																																		
C	2007	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2007	ALL	Body	Digital Radio Receiver	V	V																			V																																		
C	2007	ALL	Body	Driver Door Switch	V	V																		V	V																																		
C	2007	ALL	Body	HVAC Control Module	V	V																		V	V																																		
C	2007	ALL	Body	Inside Rear View Mirror Module	V																				V																																		
C	2007	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2007	ALL	Body	Lift Gate Module	V	V																		V	V																																		
C	2007	ALL	Body	Memory Seat Module	V	V																		V	V																																		
C	2007	ALL	Body	Park Assist Module	V	V																		V	V																																		
C	2007	ALL	Body	Passenger Door Switch	V	V																		V	V																																		
C	2007	ALL	Body	Passenger Presence System	V	V																			V																																		
C	2007	ALL	Body	Radio	V	V																		V	V																																		
C	2007	ALL	Body	Rear Heated Seat Module	V	V																			V																																		
C	2007	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2007	ALL	Body	Rollover Sensor	V	V																			V																																		
C	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2007	ALL	Body	Theft Deterrent Module	V	V																			V																																		
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V																				V														
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module	V	V																		V	V																																		
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V										V	V	V																						
C	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2008	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2008	ALL	Chassis	Trailer Brake Control Module	V	V																			V																																		
C	2008	ALL	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2008	ALL	Body	Assist Step Controller	V	V																		V	V																																		
C	2008	ALL	Body	Body Control Module	V	V																		V	V																																		
C	2008	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2008	ALL	Body	Digital Radio Receiver	V	V																			V																																		
C	2008	ALL	Body	Driver Door Switch	V	V																		V	V																																		
C	2008	ALL	Body	HVAC Control Module	V	V																		V	V																																		
C	2008	ALL	Body	Inside Rear View Mirror Module	V																				V																																		
C	2008	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2008	ALL	Body	Lift Gate Module	V	V																		V	V																																		
C	2008	ALL	Body	Memory Seat Module	V	V																		V	V																																		
C	2008	ALL	Body	Park Assist Module	V	V																		V	V																																		
C	2008	ALL	Body	Passenger Door Switch	V	V																		V	V																																		
C	2008	ALL	Body	Passenger Presence System	V	V																			V																																		
C	2008	ALL	Body	Radio	V	V																		V	V																																		
C	2008	ALL	Body	Rear Heated Seat Module	V	V																			V																																		
C	2008	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2008	ALL	Body	Rollover Sensor	V	V																			V																																		
C	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2008	ALL	Body	Theft Deterrent Module	V	V																			V																																		
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																		
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																						
C	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2009	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2009	ALL	Chassis	Trailer Brake Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2009	ALL	Body	Amplifier (Bose)	V	V																		V	V																																					
C	2009	ALL	Body	Assist Step Controller	V	V																		V	V																																					
C	2009	ALL	Body	Body Control Module	V	V																		V	V																																					
C	2009	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																					
C	2009	ALL	Body	Digital Radio Receiver	V	V																		V	V																																					
C	2009	ALL	Body	Driver Door Switch	V	V																		V	V																																					
C	2009	ALL	Body	HVAC Control Module	V	V																		V	V																																					
C	2009	ALL	Body	Inside Rear View Mirror Module	V																				V																																					
C	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																					
C	2009	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																					
C	2009	ALL	Body	Lift Gate Module	V	V																		V	V																																					
C	2009	ALL	Body	Memory Seat Module	V	V																		V	V																																					
C	2009	ALL	Body	Park Assist Module	V	V																		V	V																																					
C	2009	ALL	Body	Passenger Door Switch	V	V																		V	V																																					
C	2009	ALL	Body	Passenger Presence System	V	V																			V																																					
C	2009	ALL	Body	Radio	V	V																		V	V																																					
C	2009	ALL	Body	Rear Heated Seat Module	V	V																			V																																					
C	2009	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																					
C	2009	ALL	Body	Right Side Object Detection Module	V	V																			V																																					
C	2009	ALL	Body	Rollover Sensor	V	V																			V																																					
C	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																					
C	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																					
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V															
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																					
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V											V	V	V																									
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V														V															
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																					
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																									
C	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
C	2010	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																					
C	2010	ALL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																					
C	2010	ALL	Body	Amplifier (Bose)	V	V																		V	V																																					
C	2010	ALL	Body	Assist Step Controller	V	V																		V	V																																					
C	2010	ALL	Body	Body Control Module	V	V																		V	V																																					
C	2010	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																					
C	2010	ALL	Body	Digital Radio Receiver	V	V																		V	V																																					
C	2010	ALL	Body	Driver Door Switch	V	V																		V	V																																					
C	2010	ALL	Body	HVAC Control Module	V	V																		V	V																																					
C	2010	ALL	Body	Inside Rear View Mirror Module	V																				V																																					
C	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																					
C	2010	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																					
C	2010	ALL	Body	Lift Gate Module	V	V																		V	V																																					
C	2010	ALL	Body	Memory Seat Module	V	V																		V	V																																					
C	2010	ALL	Body	Park Assist Module	V	V																			V																																					
C	2010	ALL	Body	Passenger Door Switch	V	V																		V	V																																					
C	2010	ALL	Body	Passenger Presence System	V	V																			V																																					
C	2010	ALL	Body	Radio	V	V																		V	V																																					
C	2010	ALL	Body	Rear Heated Seat Module	V	V																			V																																					
C	2010	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																					
C	2010	ALL	Body	Right Side Object Detection Module	V	V																			V																																					
C	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2010	ALL	Body	Theft Deterrent Module	V	V																			V																																					
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V			V				V			V	V				V	V		V	V							V																													
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V																										
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V			V				V			V	V	V			V	V		V	V							V													V															
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V										V	V																										
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																			
E	2004	ALL	Chassis	Electronic Suspension Control	V	V																																																						
E	2004	ALL	Chassis	Tire Pressure Monitor	V	V																		V																																				
E	2004	ALL	Chassis	VES	V	V																		V																																				
E	2004	ALL	Body	Amplifier (Bose)	V	V																																																						
E	2004	ALL	Body	Amplifier (Delco)	V	V																		V																																				
E	2004	ALL	Body	Climate Control Panel	V	V																		V																																				
E	2004	ALL	Body	Dash Integration Module	V	V																		V																																				
E	2004	ALL	Body	Disc Player and Video Display	V																				V																																				
E	2004	ALL	Body	Driver Door Switch	V	V																																																						
E	2004	ALL	Body	Driver Door Module	V	V																		V																																				
E	2004	ALL	Body	Passenger Door Module	V	V																		V																																				
E	2004	ALL	Body	Left Rear Door Module	V	V																		V																																				
E	2004	ALL	Body	Right Rear Door Module	V	V																		V																																				
E	2004	ALL	Body	Lt. Headlamp Leveling Module	V	V																		V	V																																			
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																			
E	2004	ALL	Body	Instrument Panel Cluster	V	V																		V																																				
E	2004	ALL	Body	Memory Seat Module	V	V																		V																																				
E	2004	ALL	Body	OnStar	V	V																		V	V																																			
E	2004	ALL	Body	Personalization																																																								
E	2004	ALL	Body	Base Radio	V	V																																																					
E	2004	ALL	Body	Navigation Radio	V	V																																																					
E	2004	ALL	Body	Rear Integration Module	V	V																		V																																				
E	2004	ALL	Body	Rear Seat Module	V	V																																																					
E	2004	ALL	Body	Remote Function Actuation	V	V																																																					
E	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
E	2004	ALL	Body	TV Antenna Module	V	V																		V																																				
E	2004	ALL	Body	Vehicle Theft Deterrent	V	V																																																					
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V			V				V			V	V				V	V		V	V							V																													
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V																										
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V			V				V			V	V	V			V	V		V	V							V													V															
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V										V	V																										
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																			
E	2005	ALL	Chassis	Electronic Suspension Control	V	V																																																					
E	2005	ALL	Chassis	Tire Pressure Monitor	V	V																		V																																				
E	2005	ALL	Chassis	VES	V	V																		V																																				
E	2005	ALL	Body	Amplifier (Bose)	V	V																																																					
E	2005	ALL	Body	Amplifier (Delco)	V	V																		V																																				
E	2005	ALL	Body	Climate Control Panel	V	V																		V																																				
E	2005	ALL	Body	Dash Integration Module	V	V																		V																																				
E	2005	ALL	Body	Disc Player and Video Display	V																				V																																				
E	2005	ALL	Body	Driver Door Switch	V	V																																																					
E	2005	ALL	Body	Driver Door Module	V	V																		V																																				
E	2005	ALL	Body	Passenger Door Module	V	V																		V																																				
E	2005	ALL	Body	Left Rear Door Module	V	V																		V																																				
E	2005	ALL	Body	Right Rear Door Module	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
E	2005	ALL	Body	Lt. Headlamp Leveling Module	V	V																		V	V																																				
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																			
E	2005	ALL	Body	Instrument Panel Cluster	V	V																		V																																				
E	2005	ALL	Body	Memory Seat Module	V	V																		V																																				
E	2005	ALL	Body	Personalization																																																								
E	2005	ALL	Body	Base Radio	V	V																																																					
E	2005	ALL	Body	Navigation Radio	V	V																																																					
E	2005	ALL	Body	Rear Integration Module	V	V																		V																																				
E	2005	ALL	Body	Rear Seat Module	V	V																																																					
E	2005	ALL	Body	Remote Function Actuation	V	V																																																					
E	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
E	2005	ALL	Body	TV Antenna Module	V	V																		V																																				
E	2005	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
E	2005	ALL	Body	Vehicle Theft Deterrent	V	V																																																					
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V			V																								
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V											V	V																							
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V			V				V			V	V	V			V	V		V	V							V														V												
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V											V	V																							
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES	V	V																		V	V																																			
E	2006	ALL	Chassis	Electronic Suspension Control	V	V																																																					
E	2006	ALL	Chassis	Tire Pressure Monitor	V	V																		V																																			
E	2006	ALL	Chassis	VES	V	V																		V																																			
E	2006	ALL	Body	Amplifier (Bose)	V	V																																																				
E	2006	ALL	Body	Amplifier (Delco)	V	V																		V																																			
E	2006	ALL	Body	Climate Control Panel	V	V																		V																																			
E	2006	ALL	Body	Dash Integration Module	V	V																		V																																			
E	2006	ALL	Body	Disc Player and Video Display	V																				V																																			
E	2006	ALL	Body	Driver Door Switch	V	V																																																					
E	2006	ALL	Body	Driver Door Module	V	V																		V																																			
E	2006	ALL	Body	Passenger Door Module	V	V																		V																																			
E	2006	ALL	Body	Left Rear Door Module	V	V																		V																																			
E	2006	ALL	Body	Right Rear Door Module	V	V																		V																																			
E	2006	ALL	Body	Lt. Headlamp Leveling Module	V	V																		V	V																																			
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																			
E	2006	ALL	Body	Instrument Panel Cluster	V	V																		V																																			
E	2006	ALL	Body	Lift Gate Module	V	V																		V	V																																			
E	2006	ALL	Body	Memory Seat Module	V	V																		V																																			
E	2006	ALL	Body	Personalization																																																							
E	2006	ALL	Body	Base Radio	V	V																																																				
E	2006	ALL	Body	Navigation Radio	V	V																																																				
E	2006	ALL	Body	Rear Integration Module	V	V																		V																																			
E	2006	ALL	Body	Rear Seat Module	V	V																																																				
E	2006	ALL	Body	Remote Function Actuation	V	V																																																				
E	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
E	2006	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
E	2006	ALL	Body	Vehicle Theft Deterrent	V	V																																																				
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V															
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V											V	V																							
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V	V		V				V				V	V	V		V	V		V	V							V								V	V	V	V			V												
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V											V	V	V																						
E	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
E	2007	ALL	Chassis	Electronic Suspension Control	V	V																		V																																					
E	2007	ALL	Body	Amplifier (Bose)	V	V																		V	V																																				
E	2007	ALL	Body	Body Control Module	V	V																		V	V																																				
E	2007	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																				
E	2007	ALL	Body	Digital Radio Receiver	V	V																			V																																				
E	2007	ALL	Body	Driver Door Switch	V	V																		V	V																																				
E	2007	ALL	Body	Lt. Headlamp Leveling Module	V	V																		V	V																																				
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																				
E	2007	ALL	Body	HVAC Control Module	V	V																		V	V																																				
E	2007	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																				
E	2007	ALL	Body	Lift Gate Module	V	V																		V	V																																				
E	2007	ALL	Body	Memory Seat Module	V	V																		V	V																																				
E	2007	ALL	Body	Park Assist Module	V	V																		V	V																																				
E	2007	ALL	Body	Passenger Door Switch	V	V																		V	V																																				
E	2007	ALL	Body	Passenger Presence System	V	V																			V																																				
E	2007	ALL	Body	Radio	V	V																		V	V																																				
E	2007	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																				
E	2007	ALL	Body	Rear Seat Module	V	V																		V	V																																				
E	2007	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
E	2007	ALL	Body	Rollover Sensor	V	V																			V																																				
E	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																				
E	2007	ALL	Body	Theft Deterrent Module	V	V																			V																																				
E	2007	ALL	Body	TV Antenna Module	V	V																			V																																				
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V																								
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V		V													
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V										V	V	V																							
E	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
E	2008	ALL	Chassis	Electronic Suspension Control	V	V																		V																																				
E	2008	ALL	Body	Amplifier (Bose)	V	V																		V	V																																				
E	2008	ALL	Body	Body Control Module	V	V																		V	V																																				
E	2008	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																				
E	2008	ALL	Body	Digital Radio Receiver	V	V																		V	V																																				
E	2008	ALL	Body	Driver Door Switch	V	V																		V	V																																				
E	2008	ALL	Body	Lt. Headlamp Leveling Module	V	V																		V	V																																				
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																				
E	2008	ALL	Body	HVAC Control Module	V	V																		V	V																																				
E	2008	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																				
E	2008	ALL	Body	Lift Gate Module	V	V																		V	V																																				
E	2008	ALL	Body	Memory Seat Module	V	V																		V	V																																				
E	2008	ALL	Body	Park Assist Module	V	V																		V	V																																				
E	2008	ALL	Body	Passenger Door Switch	V	V																		V	V																																				
E	2008	ALL	Body	Passenger Presence System	V	V																			V																																				
E	2008	ALL	Body	Radio	V	V																		V	V																																				
E	2008	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																				
E	2008	ALL	Body	Rear Seat Module	V	V																		V	V																																				
E	2008	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
E	2008	ALL	Body	Rollover Sensor	V	V																			V																																				
E	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																				
E	2008	ALL	Body	Theft Deterrent Module	V	V																			V																																				
E	2008	ALL	Body	TV Antenna Module	V	V																			V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V									V	V	V	V																
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V											V	V																								
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V									V	V	V	V		V													
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module	V	V																		V											V	V	V																							
E	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
E	2009	ALL	Chassis	Electronic Suspension Control	V	V																		V																																			
E	2009	ALL	Body	Amplifier (Bose)	V	V																		V	V																																		
E	2009	ALL	Body	Body Control Module	V	V																		V	V																																		
E	2009	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																		
E	2009	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
E	2009	ALL	Body	Driver Door Switch	V	V																		V	V																																		
E	2009	ALL	Body	Lt. Headlamp Leveling Module	V	V																		V	V																																		
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.	V	V																		V	V																																		
E	2009	ALL	Body	HVAC Control Module	V	V																		V	V																																		
E	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
E	2009	ALL	Body	Lift Gate Module	V	V																		V	V																																		
E	2009	ALL	Body	Memory Seat Module	V	V																		V	V																																		
E	2009	ALL	Body	Park Assist Module	V	V																		V	V																																		
E	2009	ALL	Body	Passenger Door Switch	V	V																		V	V																																		
E	2009	ALL	Body	Passenger Presence System	V	V																			V																																		
E	2009	ALL	Body	Radio	V	V																		V	V																																		
E	2009	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																		
E	2009	ALL	Body	Rear Seat Module	V	V																		V	V																																		
E	2009	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
E	2009	ALL	Body	Rollover Sensor	V	V																			V																																		
E	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
E	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																		
E	2009	ALL	Body	TV Antenna Module	V	V																			V																																		
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V											V	V																								
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW	V	V																		V																																			
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																		
K	2004	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																		
K	2004	ALL	Chassis	ESC	V	V																		V	V																																		
K	2004	ALL	Chassis	Rear Wheel Steering	V	V																		V	V																																		
K	2004	ALL	Chassis	Tire Pressure Monitor	V	V																																																				
K	2004	ALL	Chassis	VSES	V	V																		V	V																																		
K	2004	ALL	Body	Amplifier (Bose)	V	V																			V																																		
K	2004	ALL	Body	Body Control Module	V	V																		V	V																																		
K	2004	ALL	Body	CD Changer	V																																																					
K	2004	ALL	Body	Chime	V	V																		V	V																																		
K	2004	ALL	Body	Driver Door Module	V	V																		V	V																																		
K	2004	ALL	Body	Driver Seat Module	V	V																		V	V																																		
K	2004	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																		
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																		
K	2004	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																		
K	2004	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2004	ALL	Body	OnStar	V	V																		V	V																																		
K	2004	ALL	Body	Passenger Door Module	V	V																		V	V																																		
K	2004	ALL	Body	Passenger Presence System																																																						
K	2004	ALL	Body	Base Radio	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2004	ALL	Body	Uplevel Radio	V	V																			V																																			
K	2004	ALL	Body	Navigation Radio	V	V																		V																																			
K	2004	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
K	2004	ALL	Body	Rear HVAC	V	V																			V																																			
K	2004	ALL	Body	Rear Seat Audio	V	V																			V																																			
K	2004	ALL	Body	Rear Seat Entertainment	V																				V																																			
K	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V	V		V	V						V														V														
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V										V	V																									
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum	V	V																		V	V																																			
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk	V	V																		V																																				
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																			
K	2005	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																			
K	2005	ALL	Chassis	ESC	V	V																		V	V																																			
K	2005	ALL	Chassis	Rear Wheel Steering	V	V																		V	V																																			
K	2005	ALL	Chassis	Tire Pressure Monitor	V	V																																																						
K	2005	ALL	Chassis	VSES	V	V																		V	V																																			
K	2005	ALL	Body	Amplifier (Bose)	V	V																			V																																			
K	2005	ALL	Body	Body Control Module	V	V																		V	V																																			
K	2005	ALL	Body	CD Changer	V																																																						
K	2005	ALL	Body	Chime	V	V																		V	V																																			
K	2005	ALL	Body	Disc Player and Video Display	V																				V																																			
K	2005	ALL	Body	Driver Door Module	V	V																		V	V																																			
K	2005	ALL	Body	Driver Seat Module	V	V																		V	V																																			
K	2005	ALL	Body	Generator Battery Control Module	V	V																		V	V																																			
K	2005	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																			
K	2005	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
K	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2005	ALL	Body	Passenger Door Module	V	V																		V	V																																			
K	2005	ALL	Body	Passenger Presence System																																																							
K	2005	ALL	Body	Base Radio	V	V																			V																																			
K	2005	ALL	Body	Uplevel Radio	V	V																			V																																			
K	2005	ALL	Body	Navigation Radio	V	V																		V																																			
K	2005	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
K	2005	ALL	Body	Rear HVAC	V	V																			V																																			
K	2005	ALL	Body	Rear Seat Audio	V	V																			V																																			
K	2005	ALL	Body	Remote Function Actuation	V	V																																																					
K	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
K	2005	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V	V		V	V						V														V														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V										V	V																									
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum	V	V																		V	V																																			
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk	V	V																		V																																				
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																			
K	2006	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																			
K	2006	ALL	Chassis	ESC	V	V																		V	V																																			
K	2006	ALL	Chassis	Tire Pressure Monitor	V	V																																																					
K	2006	ALL	Chassis	VSES	V	V																		V	V																																			
K	2006	ALL	Body	Amplifier (Bose)	V	V																			V																																			
K	2006	ALL	Body	Body Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2006	ALL	Body	CD Changer	V																																																								
K	2006	ALL	Body	Chime	V	V																		V	V																																			
K	2006	ALL	Body	Disc Player and Video Display	V																				V																																			
K	2006	ALL	Body	Driver Door Module	V	V																		V	V																																			
K	2006	ALL	Body	Driver Seat Module	V	V																		V	V																																			
K	2006	ALL	Body	Generator Battery Control Module	V	V																		V	V																																			
K	2006	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																			
K	2006	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
K	2006	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2006	ALL	Body	Passenger Door Module	V	V																		V	V																																			
K	2006	ALL	Body	Passenger Presence System																																																								
K	2006	ALL	Body	Base Radio	V	V																			V																																			
K	2006	ALL	Body	Uplevel Radio	V	V																			V																																			
K	2006	ALL	Body	Navigation Radio	V	V																		V																																			
K	2006	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
K	2006	ALL	Body	Rear HVAC	V	V																			V																																			
K	2006	ALL	Body	Rear Seat Audio	V	V																			V																																			
K	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
K	2006	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V																				V															
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V										V	V	V																								
K	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2007	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2007	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2007	ALL	Body	Assist Step Controller	V	V																		V	V																																			
K	2007	ALL	Body	Body Control Module	V	V																		V	V																																			
K	2007	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2007	ALL	Body	Digital Radio Receiver	V	V																			V																																			
K	2007	ALL	Body	Driver Door Switch	V	V																		V	V																																			
K	2007	ALL	Body	HVAC Control Module	V	V																		V	V																																			
K	2007	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
K	2007	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2007	ALL	Body	Lift Gate Module	V	V																		V	V																																			
K	2007	ALL	Body	Memory Seat Module	V	V																		V	V																																			
K	2007	ALL	Body	Park Assist Module	V	V																		V	V																																			
K	2007	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
K	2007	ALL	Body	Passenger Presence System	V	V																			V																																			
K	2007	ALL	Body	Radio	V	V																		V	V																																			
K	2007	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
K	2007	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2007	ALL	Body	Rollover Sensor	V	V																			V																																			
K	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2007	ALL	Body	Theft Deterrent Module	V	V																			V																																			
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V																				V															
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V										V	V	V																								
K	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2008	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2008	ALL	Chassis	Trailer Brake Control Module	V	V																			V																																			
K	2008	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2008	ALL	Body	Assist Step Controller	V	V																		V	V																																			
K	2008	ALL	Body	Body Control Module	V	V																		V	V																																		
K	2008	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2008	ALL	Body	Digital Radio Receiver	V	V																			V																																		
K	2008	ALL	Body	Driver Door Switch	V	V																		V	V																																		
K	2008	ALL	Body	HVAC Control Module	V	V																		V	V																																		
K	2008	ALL	Body	Inside Rear View Mirror Module	V																				V																																		
K	2008	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2008	ALL	Body	Lift Gate Module	V	V																		V	V																																		
K	2008	ALL	Body	Memory Seat Module	V	V																		V	V																																		
K	2008	ALL	Body	Park Assist Module	V	V																		V	V																																		
K	2008	ALL	Body	Passenger Door Switch	V	V																		V	V																																		
K	2008	ALL	Body	Passenger Presence System	V	V																			V																																		
K	2008	ALL	Body	Radio	V	V																		V	V																																		
K	2008	ALL	Body	Rear Heated Seat Module	V	V																			V																																		
K	2008	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2008	ALL	Body	Rollover Sensor	V	V																			V																																		
K	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2008	ALL	Body	Theft Deterrent Module	V	V																			V																																		
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																		
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																						
K	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
K	2009	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2009	ALL	Chassis	Trailer Brake Control Module	V	V																		V	V																																		
K	2009	ALL	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2009	ALL	Body	Assist Step Controller	V	V																		V	V																																		
K	2009	ALL	Body	Body Control Module	V	V																		V	V																																		
K	2009	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2009	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2009	ALL	Body	Driver Door Switch	V	V																		V	V																																		
K	2009	ALL	Body	HVAC Control Module	V	V																		V	V																																		
K	2009	ALL	Body	Inside Rear View Mirror Module	V																				V																																		
K	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2009	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																		
K	2009	ALL	Body	Lift Gate Module	V	V																		V	V																																		
K	2009	ALL	Body	Memory Seat Module	V	V																		V	V																																		
K	2009	ALL	Body	Park Assist Module	V	V																		V	V																																		
K	2009	ALL	Body	Passenger Door Switch	V	V																		V	V																																		
K	2009	ALL	Body	Passenger Presence System	V	V																			V																																		
K	2009	ALL	Body	Radio	V	V																		V	V																																		
K	2009	ALL	Body	Rear Heated Seat Module	V	V																			V																																		
K	2009	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2009	ALL	Body	Right Side Object Detection Module	V	V																			V																																		
K	2009	ALL	Body	Rollover Sensor	V	V																			V																																		
K	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																		
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																		
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V											V	V	V																						
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V														V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																				
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																							
K	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2010	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2010	ALL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2010	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2010	ALL	Body	Assist Step Controller	V	V																		V	V																																			
K	2010	ALL	Body	Body Control Module	V	V																		V	V																																			
K	2010	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2010	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2010	ALL	Body	Driver Door Switch	V	V																		V	V																																			
K	2010	ALL	Body	HVAC Control Module	V	V																		V	V																																			
K	2010	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
K	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2010	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2010	ALL	Body	Lift Gate Module	V	V																		V	V																																			
K	2010	ALL	Body	Memory Seat Module	V	V																		V	V																																			
K	2010	ALL	Body	Park Assist Module	V	V																			V																																			
K	2010	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
K	2010	ALL	Body	Passenger Presence System	V	V																			V																																			
K	2010	ALL	Body	Radio	V	V																		V	V																																			
K	2010	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
K	2010	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2010	ALL	Body	Right Side Object Detection Module	V	V																			V																																			
K	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2010	ALL	Body	Theft Deterrent Module	V	V																			V																																			
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module	V																			V	V					V	V	V	V								V	V	V	V																
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module	V	V																		V	V							V		V																										
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module	V	V																		V	V										V		V																							
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V														
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module	V	V																		V	V							V		V																										
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V												
N	2010	SRX	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						V
N	2010	SRX	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																															V	V		
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
N	2010	SRX	Chassis	Suspension Control Module	V	V																		V	V																																			
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
N	2010	SRX	Body	Passenger Presence Module	V	V																			V																																			
N	2010	SRX	Body	Instrument Cluster	V	V																		V	V																																			
N	2010	SRX	Body	Headlamp Control Module	V	V																		V	V																																			
N	2010	SRX	Body	Trailer Interface Control Module	V	V																		V	V																																			
N	2010	SRX	Body	Radio	V	V																		V	V																																			
N	2010	SRX	Body	Rear Audio Control Module	V	V																		V	V																																			
N	2010	SRX	Body	Digital Radio Receiver Control Module	V	V																			V																																			
N	2010	SRX	Body	Multimedia Player Interface Module	V	V																			V																																			
N	2010	SRX	Body	Mobile Telephone Control Module	V	V																		V	V																																			
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)	V	V																		V	V																																			
N	2010	SRX	Body	Liftgate Control Module	V	V																			V																						V													
N	2010	SRX	Body	Seat Memory Control Module	V	V																		V	V																																			
N	2010	SRX	Body	Front Seat Heating Control Module	V	V																		V	V																																			
N	2010	SRX	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry	V																				V																																			
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)	V	V																		V	V																																			
N	2010	SRX	Body	Parking Assist Control Module	V	V																		V	V																																			
N	2010	SRX	Body	Steering Column Lock Control Module	V	V																			V																																			
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module	V																			V	V					V	V	V	V								V	V	V	V																
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module	V	V																		V	V							V		V																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module	V	V																		V	V										V		V																							
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V															
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module	V	V																		V	V							V		V																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module	V	V																		V	V										V	V	V	V								V														
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V													
N	2011	SRX	Chassis	Electronic Brake Control Module	V	V																		V	V												V												V	V	V	V	V	V						V
N	2011	SRX	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V			
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
N	2011	SRX	Chassis	Suspension Control Module	V	V																		V	V																																			
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																			
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																			
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
N	2011	SRX	Body	Passenger Presence Module	V	V																			V																																			
N	2011	SRX	Body	Instrument Cluster	V	V																		V	V																																			
N	2011	SRX	Body	Headlamp Control Module	V	V																		V	V																																			
N	2011	SRX	Body	Trailer Interface Control Module	V	V																		V	V																																			
N	2011	SRX	Body	Radio	V	V																		V	V																																			
N	2011	SRX	Body	Rear Audio Control Module	V	V																		V	V																																			
N	2011	SRX	Body	Digital Radio Receiver Control Module	V	V																			V																																			
N	2011	SRX	Body	Multimedia Player Interface Module	V	V																			V																																			
N	2011	SRX	Body	Mobile Telephone Control Module	V	V																		V	V																																			
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)	V	V																		V	V																																			
N	2011	SRX	Body	Liftgate Control Module	V	V																			V																						V													
N	2011	SRX	Body	Seat Memory Control Module	V																																																							
N	2011	SRX	Body	Front Seat Heating Control Module	V	V																		V	V																																			
N	2011	SRX	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry	V																				V																																			
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)	V	V																		V	V																																			
N	2011	SRX	Body	Parking Assist Control Module	V	V																		V	V																																			
N	2011	SRX	Body	Steering Column Lock Control Module	V	V																			V																																			
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V															
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module	V	V																		V	V							V		V																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V										V	V	V	V								V														
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V		V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module	V	V																		V	V							V		V																											
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V										V													
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																							V												
N	2012	SRX	Chassis	Electronic Brake Control Module	V	V																		V	V												V												V	V	V	V	V	V						V
N	2012	SRX	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
N	2012	SRX	Chassis	Suspension Control Module	V	V																		V	V																																	
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																	
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																	
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
N	2012	SRX	Body	Passenger Presence Module	V	V																			V																																	
N	2012	SRX	Body	Instrument Cluster	V	V																		V	V																																	
N	2012	SRX	Body	Headlamp Control Module	V	V																		V	V																																	
N	2012	SRX	Body	Trailer Interface Control Module	V	V																		V	V																																	
N	2012	SRX	Body	Radio	V	V																		V	V																																	
N	2012	SRX	Body	Rear Audio Control Module	V	V																		V	V																																	
N	2012	SRX	Body	Digital Radio Receiver Control Module	V	V																			V																																	
N	2012	SRX	Body	Multimedia Player Interface Module	V	V																			V																																	
N	2012	SRX	Body	Mobile Telephone Control Module	V	V																		V	V																																	
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																	
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)	V	V																		V	V																																	
N	2012	SRX	Body	Liftgate Control Module	V	V																			V																						V												
N	2012	SRX	Body	Seat Memory Control Module	V																																																					
N	2012	SRX	Body	Front Seat Heating Control Module	V	V																		V	V																																	
N	2012	SRX	Body	Rear Seat Heating Control Module	V	V																		V	V																																	
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry	V																				V																																	
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)	V	V																		V	V																																	
N	2012	SRX	Body	Parking Assist Control Module	V	V																		V	V																																	
N	2012	SRX	Body	Steering Column Lock Control Module	V	V																			V																																	
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V			V	V	V	V	V								V	V	V	V		V													
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V									V													
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V			V	V	V	V	V								V	V	V	V		V													
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V													
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V												
N	2013	SRX	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						V
N	2013	SRX	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
N	2013	SRX	Chassis	Suspension Control Module	V	V																		V	V																																	
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																	
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																	
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
N	2013	SRX	Body	Passenger Presence Module	V	V																			V																																	
N	2013	SRX	Body	Instrument Cluster	V	V																		V	V																																	
N	2013	SRX	Body	Radio/HVAC Control	V																																																				
N	2013	SRX	Body	Active Safety Control Module	V	V																		V	V																						V												
N	2013	SRX	Body	Headlamp Control Module	V	V																		V	V																																	
N	2013	SRX	Body	Trailer Interface Control Module	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
N	2013	SRX	Body	Radio	V	V																		V	V																																			
N	2013	SRX	Body	Amplifier	V	V																			V																																		
N	2013	SRX	Body	Media Disc Player	V	V																		V	V																																		
N	2013	SRX	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																		
N	2013	SRX	Body	Liftgate Control Module	V	V																			V																							V											
N	2013	SRX	Body	Seat Memory Control Module	V																																																						
N	2013	SRX	Body	Rear Seat Heating Control Module	V	V																		V	V																																		
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry	V																				V																																		
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)	V	V																		V	V																																		
N	2013	SRX	Body	Right Side Object Detection Control Module	V																			V	V																																		
N	2013	SRX	Body	Left Side Object Detection Control Module	V																			V	V																																		
N	2013	SRX	Body	Parking Assist Control Module	V	V																		V	V																																		
N	2013	SRX	Body	Frontview Camera Module	V	V																		V	V																																		
N	2013	SRX	Body	Steering Column Lock Control Module	V	V																			V																																		
N	2013	SRX	Body	Long Range Radar Sensor Module	V	V																			V																																		
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module	V																				V																																		
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module	V																				V																																		
N	2013	SRX	Body	Rear Short Range Radar Sensor Module	V																				V																																		
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V										V	V	V	V									V												
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V												
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																							V											
N	2014	SRX	Chassis	Electronic Brake Control Module	V	V																		V	V													V												V	V	V	V	V	V						V
N	2014	SRX	Chassis	Parking Brake Control Module	V	V																			V																							V								V	V	V	V		
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
N	2014	SRX	Chassis	Suspension Control Module	V	V																		V	V																																		
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																		
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
N	2014	SRX	Body	Passenger Presence Module	V	V																			V																																		
N	2014	SRX	Body	Instrument Cluster	V	V																		V	V																																		
N	2014	SRX	Body	Radio/HVAC Control	V																				V																																		
N	2014	SRX	Body	Active Safety Control Module	V	V																		V	V																							V											
N	2014	SRX	Body	Headlamp Control Module	V	V																		V	V																																		
N	2014	SRX	Body	Trailer Interface Control Module	V	V																		V	V																																		
N	2014	SRX	Body	Radio	V	V																		V	V																																		
N	2014	SRX	Body	Amplifier	V	V																			V																																		
N	2014	SRX	Body	Media Disc Player	V	V																		V	V																																		
N	2014	SRX	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
N	2014	SRX	Body	Navigation Control Module	V	V																			V																																		
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																		
N	2014	SRX	Body	Liftgate Control Module	V	V																			V																							V											

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
N	2014	SRX	Body	Seat Memory Control Module - Driver	V																																																							
N	2014	SRX	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry	V	V																			V																																			
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)	V	V																		V	V																																			
N	2014	SRX	Body	Right Side Object Detection Control Module	V																			V	V																																			
N	2014	SRX	Body	Left Side Object Detection Control Module	V																			V	V																																			
N	2014	SRX	Body	Parking Assist Control Module	V	V																		V	V																																			
N	2014	SRX	Body	Frontview Camera Module	V	V																		V	V																																			
N	2014	SRX	Body	Steering Column Lock Control Module	V	V																			V																																			
N	2014	SRX	Body	Long Range Radar Sensor Module	V	V																			V																																			
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
N	2014	SRX	Body	Rear Short Range Radar Sensor Module	V																				V																																			
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V										V												
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V												
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																						V											
N	2015	SRX	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V					V
N	2015	SRX	Chassis	Parking Brake Control Module	V	V																			V																						V						V	V	V	V		
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
N	2015	SRX	Chassis	Suspension Control Module	V	V																		V	V																																		
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																		V	V																																		
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																		V	V																																		
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
N	2015	SRX	Body	Passenger Presence Module	V	V																			V																																		
N	2015	SRX	Body	Instrument Cluster	V	V																		V	V																																		
N	2015	SRX	Body	Radio/HVAC Control	V																				V																																		
N	2015	SRX	Body	Active Safety Control Module	V	V																		V	V																						V												
N	2015	SRX	Body	Headlamp Control Module	V	V																		V	V																																		
N	2015	SRX	Body	Trailer Interface Control Module	V	V																		V	V																																		
N	2015	SRX	Body	Radio	V	V																		V	V																																		
N	2015	SRX	Body	Amplifier	V	V																			V																																		
N	2015	SRX	Body	Rear Audio Control Module	V	V																		V	V																																		
N	2015	SRX	Body	Media Disc Player	V	V																		V	V																																		
N	2015	SRX	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
N	2015	SRX	Body	Navigation Control Module	V	V																			V																																		
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																		V	V																																		
N	2015	SRX	Body	Liftgate Control Module	V	V																			V																						V												
N	2015	SRX	Body	Seat Memory Control Module - Driver	V																																																						
N	2015	SRX	Body	Rear Seat Heating Control Module	V	V																		V	V																																		
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry	V	V																			V																																		
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)	V	V																		V	V																																		
N	2015	SRX	Body	Right Side Object Detection Control Module	V																			V	V																																		
N	2015	SRX	Body	Left Side Object Detection Control Module	V																			V	V																																		
N	2015	SRX	Body	Parking Assist Control Module	V	V																		V	V																																		
N	2015	SRX	Body	Frontview Camera Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
N	2015	SRX	Body	Steering Column Lock Control Module	V	V																			V																																			
N	2015	SRX	Body	Long Range Radar Sensor Module	V	V																			V																																			
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
N	2015	SRX	Body	Rear Short Range Radar Sensor Module	V																				V																																			
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module	V																		V	V			V	V	V	V	V							V	V	V	V	V	V																
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																	V	V									V	V	V	V								V																
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module	V																		V	V			V	V	V	V	V							V	V	V	V	V	V																
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																	V	V									V	V	V	V								V																
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module	V	V																	V	V																					V															
N	2016	SRX	Chassis	Electronic Brake Control Module	V	V																	V	V												V										V	V	V	V	V	V							V
N	2016	SRX	Chassis	Parking Brake Control Module	V	V																		V																					V							V	V	V	V				
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																		V	V
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module	V																			V																																				
N	2016	SRX	Chassis	Suspension Control Module	V	V																	V	V																																				
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)	V	V																	V	V																																				
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)	V	V																	V	V																																				
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																				
N	2016	SRX	Body	Passenger Presence Module	V	V																		V																																				
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)	V	V																	V	V																																				
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)	V	V																	V	V																																				
N	2016	SRX	Body	Radio/HVAC Control	V																			V																																				
N	2016	SRX	Body	Active Safety Control Module	V	V																	V	V																					V															
N	2016	SRX	Body	Headlamp Control Module	V	V																	V	V																																				
N	2016	SRX	Body	Trailer Interface Control Module	V	V																	V	V																																				
N	2016	SRX	Body	Radio	V	V																	V	V																																				
N	2016	SRX	Body	Amplifier	V	V																		V																																				
N	2016	SRX	Body	Rear Audio Control Module	V	V																	V	V																																				
N	2016	SRX	Body	Media Disc Player	V	V																	V	V																																				
N	2016	SRX	Body	Human Machine Interface Control Module	V	V																	V	V																					V															
N	2016	SRX	Body	Navigation Control Module	V	V																		V																																				
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7	V	V																	V	V																																				
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																				
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																	V	V																																				
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)	V	V																	V	V																																				
N	2016	SRX	Body	Liftgate Control Module	V	V																	V	V																					V															
N	2016	SRX	Body	Seat Memory Control Module - Driver	V																																																							
N	2016	SRX	Body	Rear Seat Heating Control Module	V	V																	V	V																																				
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry	V	V																		V																																				
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)	V	V																	V	V																																				
N	2016	SRX	Body	Right Side Object Detection Control Module	V																		V	V																																				
N	2016	SRX	Body	Left Side Object Detection Control Module	V																		V	V																																				
N	2016	SRX	Body	Parking Assist Control Module	V	V																	V	V																																				
N	2016	SRX	Body	Frontview Camera Module	V	V																	V	V																																				
N	2016	SRX	Body	Steering Column Lock Control Module	V	V																		V																																				
N	2016	SRX	Body	Long Range Radar Sensor Module	V	V																		V																																				
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module	V																			V																																				
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module	V																			V																																				
N	2016	SRX	Body	Rear Short Range Radar Sensor Module	V																			V																																				
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V												V																	
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V											V	V	V																								
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V														
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																							
3	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
3	2011	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
3	2011	ALL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
3	2011	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
3	2011	ALL	Body	Assist Step Controller	V	V																		V	V																																			
3	2011	ALL	Body	Body Control Module	V	V																		V	V																																			
3	2011	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																			
3	2011	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
3	2011	ALL	Body	Driver Door Switch	V	V																		V	V																																			
3	2011	ALL	Body	HVAC Control Module	V	V																		V	V																																			
3	2011	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
3	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
3	2011	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																			
3	2011	ALL	Body	Lift Gate Module	V	V																		V	V																																			
3	2011	ALL	Body	Memory Seat Module	V	V																		V	V																																			
3	2011	ALL	Body	Park Assist Module	V	V																			V																																			
3	2011	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
3	2011	ALL	Body	Passenger Presence System	V	V																			V																																			
3	2011	ALL	Body	Radio	V	V																		V	V																																			
3	2011	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
3	2011	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
3	2011	ALL	Body	Right Side Object Detection Module	V	V																			V																																			
3	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
3	2011	ALL	Body	Theft Deterrent Module	V	V																			V																																			
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V											V	V	V																							
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																							
3	2012	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
3	2012	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
3	2012	ALL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
3	2012	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
3	2012	ALL	Body	Assist Step Controller	V	V																		V	V																																			
3	2012	ALL	Body	Body Control Module	V	V																		V	V																																			
3	2012	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																			
3	2012	ALL	Body	Driver Door Switch	V	V																		V	V																																			
3	2012	ALL	Body	HVAC Control Module	V	V																		V	V																																			
3	2012	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
3	2012	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
3	2012	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																			
3	2012	ALL	Body	Lift Gate Module	V	V																		V	V																																			
3	2012	ALL	Body	Memory Seat Module	V	V																		V	V																																			
3	2012	ALL	Body	Park Assist Module	V	V																			V																																			
3	2012	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
3	2012	ALL	Body	Passenger Presence System	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
3	2012	ALL	Body	Radio	V	V																		V	V																																			
3	2012	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
3	2012	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
3	2012	ALL	Body	Right Side Object Detection Module	V	V																			V																																			
3	2012	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
3	2012	ALL	Body	Theft Deterrent Module	V	V																			V																																			
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																								
3	2013	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
3	2013	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
3	2013	ALL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
3	2013	ALL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
3	2013	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
3	2013	ALL	Body	Assist Step Controller	V	V																		V	V																																			
3	2013	ALL	Body	Body Control Module	V	V																		V	V																																			
3	2013	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																			
3	2013	ALL	Body	Driver Door Switch	V	V																		V	V																																			
3	2013	ALL	Body	HVAC Control Module	V	V																		V	V																																			
3	2013	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
3	2013	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
3	2013	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																			
3	2013	ALL	Body	Lift Gate Module	V	V																		V	V																																			
3	2013	ALL	Body	Memory Seat Module	V	V																		V	V																																			
3	2013	ALL	Body	Park Assist Module	V	V																			V																																			
3	2013	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
3	2013	ALL	Body	Passenger Presence System	V	V																			V																																			
3	2013	ALL	Body	Radio	V	V																		V	V																																			
3	2013	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
3	2013	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
3	2013	ALL	Body	Right Side Object Detection Module	V	V																			V																																			
3	2013	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
3	2013	ALL	Body	Theft Deterrent Module	V	V																			V																																			
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module	V																			V	V	V			V	V	V	V	V													V														
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module	V	V																		V	V										V	V	V	V										V													
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V																												
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control	V	V									V									V	V							V																												
3	2014	Escalade	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						V
3	2014	Escalade	Chassis	Suspension Control Module	V	V																		V	V																																			
3	2014	Escalade	Body	Body Control Module	V	V																		V	V																																			
3	2014	Escalade	Body	Auxiliary Body Control Module	V	V																		V	V																																			
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
3	2014	Escalade	Body	Passenger Presence Module	V	V																			V																																			
3	2014	Escalade	Body	Instrument Cluster	V	V																		V	V																																			
3	2014	Escalade	Body	Radio	V	V																		V	V																																			
3	2014	Escalade	Body	Amplifier	V	V																			V																																			
3	2014	Escalade	Body	Rear Audio Control Module	V	V																			V																																			
3	2014	Escalade	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
3	2014	Escalade	Body	Personal Audio Link Control Module	V																				V																																			
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
3	2014	Escalade	Body	HVAC Control Module	V	V																		V	V																																			
3	2014	Escalade	Body	Driver Door Switch Panel Control Module	V	V																		V	V																					V												
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																	
3	2014	Escalade	Body	Liftgate Control Module	V	V																			V																					V												
3	2014	Escalade	Body	Seat Memory Control Module	V	V																		V	V																																	
3	2014	Escalade	Body	Rear Seat Heating Control Module	V	V																		V	V																																	
3	2014	Escalade	Body	Assist Step Control Module	V	V																		V	V																																	
3	2014	Escalade	Body	Right Side Object Detection Control Module	V	V																		V	V																																	
3	2014	Escalade	Body	Left Side Object Detection Control Module	V	V																		V	V																																	
3	2014	Escalade	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
3	2014	Escalade	Body	Parking Assist Control Module	V	V																		V	V																																	
3	2014	Escalade	Body	Theft Deterrent Module	V	V																			V																																	
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module	V																			V	V	V			V	V	V	V	V												V												
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module	V	V																		V	V										V	V	V	V									V											
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V																										
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control	V	V									V									V	V							V																										
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						V
3	2014	Escalade ESV	Chassis	Suspension Control Module	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Body Control Module	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Auxiliary Body Control Module	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
3	2014	Escalade ESV	Body	Passenger Presence Module	V	V																			V																																	
3	2014	Escalade ESV	Body	Instrument Cluster	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Radio	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Amplifier	V	V																			V																																	
3	2014	Escalade ESV	Body	Rear Audio Control Module	V	V																			V																																	
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Personal Audio Link Control Module	V																				V																																	
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
3	2014	Escalade ESV	Body	HVAC Control Module	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module	V	V																		V	V																					V												
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Liftgate Control Module	V	V																			V																					V												
3	2014	Escalade ESV	Body	Seat Memory Control Module	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Assist Step Control Module	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Parking Assist Control Module	V	V																		V	V																																	
3	2014	Escalade ESV	Body	Theft Deterrent Module	V	V																			V																																	
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V			V	V	V	V	V												V												
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V								V	V	V	V									V												
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V								V	V	V	V		V																		
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																	
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																	
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control	V	V																		V	V																																	
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																	
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																	
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
3	2015	Escalade	Powertrain	Drive Motor Control Module 1		V																			V																																				
3	2015	Escalade	Powertrain	Drive Motor Control Module 2		V																			V																																				
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																				
3	2015	Escalade	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V							
3	2015	Escalade	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																				
3	2015	Escalade	Chassis	Power Steering Control Module	V	V																		V	V																																				
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module	V																				V																																				
3	2015	Escalade	Chassis	Suspension Control Module	V	V																		V	V																																				
3	2015	Escalade	Body	Body Control Module	V	V																		V	V																																				
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																				
3	2015	Escalade	Body	Passenger Presence Module	V	V																			V																																				
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left	V	V																			V																																				
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right	V	V																			V																																				
3	2015	Escalade	Body	Instrument Cluster	V	V																		V	V																																				
3	2015	Escalade	Body	Radio/HVAC Control	V																				V																																				
3	2015	Escalade	Body	Active Safety Control Module	V	V																		V	V																					V															
3	2015	Escalade	Body	Video Processing Control Module	V	V																		V	V																																				
3	2015	Escalade	Body	Radio	V	V																		V	V																																				
3	2015	Escalade	Body	Amplifier	V	V																			V																																				
3	2015	Escalade	Body	Media Disc Player	V	V																		V	V																																				
3	2015	Escalade	Body	Human Machine Interface Control Module	V	V																		V	V																					V															
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																				
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																				
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																				
3	2015	Escalade	Body	HVAC Control Module	V	V																		V	V																																				
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)	V	V																		V	V																					V															
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)	V	V																			V																					V															
3	2015	Escalade	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																				
3	2015	Escalade	Body	Seat Memory Control Module - Driver	V																																																							
3	2015	Escalade	Body	Keyless Entry Control Module	V	V																		V	V																																				
3	2015	Escalade	Body	Assist Step Control Module	V	V																		V	V																																				
3	2015	Escalade	Body	Left Side Object Detection Control Module	V																			V	V																																				
3	2015	Escalade	Body	Parking Assist Control Module	V																			V	V																																				
3	2015	Escalade	Body	Frontview Camera Module	V	V																		V	V																																				
3	2015	Escalade	Body	Steering Column Lock Control Module	V	V																			V																																				
3	2015	Escalade	Body	Battery Energy Control Module		V																			V																																				
3	2015	Escalade	Body	Long Range Radar Sensor Module	V	V																			V																																				
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module	V																				V																																				
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module	V																				V																																				
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module	V																				V																																				
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module	V																				V																																				
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V															
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V															
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																				
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																				
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																				
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control	V	V																		V	V																																				
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																				
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																				
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																				
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V							
3	2015	Escalade ESV	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
3	2015	Escalade ESV	Chassis	Power Steering Control Module	V	V																		V	V																																			
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
3	2015	Escalade ESV	Chassis	Suspension Control Module	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Body Control Module	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Passenger Presence Module	V	V																			V																																			
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left	V	V																			V																																			
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right	V	V																			V																																			
3	2015	Escalade ESV	Body	Instrument Cluster	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Radio/HVAC Control	V																				V																																			
3	2015	Escalade ESV	Body	Active Safety Control Module	V	V																		V	V																					V														
3	2015	Escalade ESV	Body	Video Processing Control Module	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Radio	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Amplifier	V	V																			V																																			
3	2015	Escalade ESV	Body	Media Disc Player	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Human Machine Interface Control Module	V	V																		V	V																					V														
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
3	2015	Escalade ESV	Body	HVAC Control Module	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)	V	V																		V	V																					V														
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)	V	V																			V																					V														
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver	V																																																						
3	2015	Escalade ESV	Body	Keyless Entry Control Module	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Assist Step Control Module	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module	V																			V	V																																			
3	2015	Escalade ESV	Body	Parking Assist Control Module	V																			V	V																																			
3	2015	Escalade ESV	Body	Frontview Camera Module	V	V																		V	V																																			
3	2015	Escalade ESV	Body	Steering Column Lock Control Module	V	V																			V																																			
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module	V	V																			V																																			
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module	V																				V																																			
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module	V																				V																																			
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V			V	V	V	V	V													V														
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V														
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																			
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
3	2016	Escalade	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V							
3	2016	Escalade	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
3	2016	Escalade	Chassis	Power Steering Control Module	V	V																		V	V																																			
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
3	2016	Escalade	Chassis	Suspension Control Module	V	V																		V	V																																			
3	2016	Escalade	Body	Body Control Module	V	V																		V	V																																			
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
3	2016	Escalade	Body	Passenger Presence Module	V	V																			V																																			
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left	V	V																			V																																			
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right	V	V																			V																																			
3	2016	Escalade	Body	Instrument Cluster	V	V																		V	V																																			
3	2016	Escalade	Body	Radio/HVAC Control	V																				V																																			
3	2016	Escalade	Body	Active Safety Control Module	V	V																		V	V																							V											
3	2016	Escalade	Body	Video Processing Control Module	V	V																		V	V																																			
3	2016	Escalade	Body	Radio	V	V																		V	V																																			
3	2016	Escalade	Body	Amplifier	V	V																			V																																			
3	2016	Escalade	Body	Media Disc Player	V	V																		V	V																																			
3	2016	Escalade	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
3	2016	Escalade	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
3	2016	Escalade	Body	HVAC Control Module	V	V																		V	V																																			
3	2016	Escalade	Body	Liftgate Control Module	V	V																		V	V																							V											
3	2016	Escalade	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
3	2016	Escalade	Body	Seat Memory Control Module - Driver	V																																																							
3	2016	Escalade	Body	Keyless Entry Control Module	V	V																		V	V																																			
3	2016	Escalade	Body	Assist Step Control Module	V	V																		V	V																																			
3	2016	Escalade	Body	Left Side Object Detection Control Module	V																			V	V																																			
3	2016	Escalade	Body	Parking Assist Control Module	V																			V	V																																			
3	2016	Escalade	Body	Frontview Camera Module	V	V																		V	V																																			
3	2016	Escalade	Body	Steering Column Lock Control Module	V	V																			V																																			
3	2016	Escalade	Body	Long Range Radar Sensor Module	V	V																			V																																			
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module	V																				V																																			
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module	V																				V																																			
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V														
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V													
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																			
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
3	2016	Escalade ESV	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
3	2016	Escalade ESV	Chassis	Power Steering Control Module	V	V																		V	V																																			
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
3	2016	Escalade ESV	Chassis	Suspension Control Module	V	V																		V	V																																			
3	2016	Escalade ESV	Body	Body Control Module	V	V																		V	V																																			
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
3	2016	Escalade ESV	Body	Passenger Presence Module	V	V																			V																																			
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left	V	V																			V																																			
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right	V	V																			V																																			
3	2016	Escalade ESV	Body	Instrument Cluster	V	V																		V	V																																			
3	2016	Escalade ESV	Body	Radio Control	V																				V																																			
3	2016	Escalade ESV	Body	HVAC Control	V																			V	V																																			
3	2016	Escalade ESV	Body	Active Safety Control Module	V	V																		V	V																							V											
3	2016	Escalade ESV	Body	Video Processing Control Module	V	V																		V	V																																			
3	2016	Escalade ESV	Body	Radio	V	V																		V	V																																			
3	2016	Escalade ESV	Body	Amplifier	V	V																			V																																			
3	2016	Escalade ESV	Body	Media Disc Player	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
3	2016	Escalade ESV	Body	Human Machine Interface Control Module	V	V																		V	V																					V														
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
3	2016	Escalade ESV	Body	HVAC Control Module	V	V																		V	V																																			
3	2016	Escalade ESV	Body	Liftgate Control Module	V	V																		V	V																					V													
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver	V																																																						
3	2016	Escalade ESV	Body	Keyless Entry Control Module	V	V																		V	V																																			
3	2016	Escalade ESV	Body	Assist Step Control Module	V	V																		V	V																																			
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module	V																			V	V																																			
3	2016	Escalade ESV	Body	Parking Assist Control Module	V																			V	V																																			
3	2016	Escalade ESV	Body	Frontview Camera Module	V	V																		V	V																																			
3	2016	Escalade ESV	Body	Steering Column Lock Control Module	V	V																			V																																			
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module	V	V																			V																																			
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module	V																				V																																			
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module	V																				V																																			
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																							
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V														
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
4	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
4	2011	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
4	2011	ALL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
4	2011	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
4	2011	ALL	Body	Assist Step Controller	V	V																		V	V																																			
4	2011	ALL	Body	Body Control Module	V	V																		V	V																																			
4	2011	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																			
4	2011	ALL	Body	Driver Door Switch	V	V																		V	V																																			
4	2011	ALL	Body	HVAC Control Module	V	V																		V	V																																			
4	2011	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
4	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
4	2011	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																			
4	2011	ALL	Body	Lift Gate Module	V	V																		V	V																																			
4	2011	ALL	Body	Memory Seat Module	V	V																		V	V																																			
4	2011	ALL	Body	Park Assist Module	V	V																			V																																			
4	2011	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
4	2011	ALL	Body	Passenger Presence System	V	V																			V																																			
4	2011	ALL	Body	Radio	V	V																		V	V																																			
4	2011	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
4	2011	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
4	2011	ALL	Body	Right Side Object Detection Module	V	V																			V																																			
4	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
4	2011	ALL	Body	Theft Deterrent Module	V	V																			V																																			
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																							
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																								
4	2012	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
4	2012	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
4	2012	ALL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
4	2012	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
4	2012	ALL	Body	Assist Step Controller	V	V																		V	V																																			
4	2012	ALL	Body	Body Control Module	V	V																		V	V																																			
4	2012	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																			
4	2012	ALL	Body	Driver Door Switch	V	V																		V	V																																			
4	2012	ALL	Body	HVAC Control Module	V	V																		V	V																																			
4	2012	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
4	2012	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
4	2012	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																			
4	2012	ALL	Body	Lift Gate Module	V	V																		V	V																																			
4	2012	ALL	Body	Memory Seat Module	V	V																		V	V																																			
4	2012	ALL	Body	Park Assist Module	V	V																			V																																			
4	2012	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
4	2012	ALL	Body	Passenger Presence System	V	V																			V																																			
4	2012	ALL	Body	Radio	V	V																		V	V																																			
4	2012	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
4	2012	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
4	2012	ALL	Body	Right Side Object Detection Module	V	V																			V																																			
4	2012	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
4	2012	ALL	Body	Theft Deterrent Module	V	V																			V																																			
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																								
4	2013	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
4	2013	ALL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
4	2013	ALL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
4	2013	ALL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
4	2013	ALL	Body	Amplifier (Bose)	V	V																		V	V																																			
4	2013	ALL	Body	Assist Step Controller	V	V																		V	V																																			
4	2013	ALL	Body	Body Control Module	V	V																		V	V																																			
4	2013	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																			
4	2013	ALL	Body	Driver Door Switch	V	V																		V	V																																			
4	2013	ALL	Body	HVAC Control Module	V	V																		V	V																																			
4	2013	ALL	Body	Inside Rear View Mirror Module	V																				V																																			
4	2013	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
4	2013	ALL	Body	Left Side Object Detection Module	V	V																		V	V																																			
4	2013	ALL	Body	Lift Gate Module	V	V																		V	V																																			
4	2013	ALL	Body	Memory Seat Module	V	V																		V	V																																			
4	2013	ALL	Body	Park Assist Module	V	V																			V																																			
4	2013	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
4	2013	ALL	Body	Passenger Presence System	V	V																			V																																			
4	2013	ALL	Body	Radio	V	V																		V	V																																			
4	2013	ALL	Body	Rear Heated Seat Module	V	V																			V																																			
4	2013	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
4	2013	ALL	Body	Right Side Object Detection Module	V	V																			V																																			
4	2013	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
4	2013	ALL	Body	Theft Deterrent Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module	V																			V	V	V			V	V	V	V	V												V															
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V																											
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control	V	V									V									V	V							V																											
4	2014	Escalade	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
4	2014	Escalade	Chassis	Suspension Control Module	V	V																		V	V																																		
4	2014	Escalade	Body	Body Control Module	V	V																		V	V																																		
4	2014	Escalade	Body	Auxiliary Body Control Module	V	V																		V	V																																		
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
4	2014	Escalade	Body	Passenger Presence Module	V	V																			V																																		
4	2014	Escalade	Body	Instrument Cluster	V	V																		V	V																																		
4	2014	Escalade	Body	Radio	V	V																		V	V																																		
4	2014	Escalade	Body	Amplifier	V	V																			V																																		
4	2014	Escalade	Body	Rear Audio Control Module	V	V																			V																																		
4	2014	Escalade	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
4	2014	Escalade	Body	Personal Audio Link Control Module	V																				V																																		
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
4	2014	Escalade	Body	HVAC Control Module	V	V																		V	V																																		
4	2014	Escalade	Body	Driver Door Switch Panel Control Module	V	V																		V	V																							V											
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
4	2014	Escalade	Body	Liftgate Control Module	V	V																			V																							V											
4	2014	Escalade	Body	Seat Memory Control Module	V	V																		V	V																																		
4	2014	Escalade	Body	Rear Seat Heating Control Module	V	V																		V	V																																		
4	2014	Escalade	Body	Assist Step Control Module	V	V																		V	V																																		
4	2014	Escalade	Body	Right Side Object Detection Control Module	V	V																		V	V																																		
4	2014	Escalade	Body	Left Side Object Detection Control Module	V	V																		V	V																																		
4	2014	Escalade	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
4	2014	Escalade	Body	Parking Assist Control Module	V	V																		V	V																																		
4	2014	Escalade	Body	Theft Deterrent Module	V	V																			V																																		
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module	V																			V	V	V			V	V	V	V	V												V															
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V																											
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control	V	V									V									V	V							V																											
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
4	2014	Escalade ESV	Chassis	Suspension Control Module	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Body Control Module	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Auxiliary Body Control Module	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
4	2014	Escalade ESV	Body	Passenger Presence Module	V	V																			V																																		
4	2014	Escalade ESV	Body	Instrument Cluster	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Radio	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Amplifier	V	V																			V																																		
4	2014	Escalade ESV	Body	Rear Audio Control Module	V	V																			V																																		
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Personal Audio Link Control Module	V																				V																																		
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
4	2014	Escalade ESV	Body	HVAC Control Module	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module	V	V																		V	V																							V											
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
4	2014	Escalade ESV	Body	Liftgate Control Module	V	V																			V																					V													
4	2014	Escalade ESV	Body	Seat Memory Control Module	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Assist Step Control Module	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Parking Assist Control Module	V	V																		V	V																																		
4	2014	Escalade ESV	Body	Theft Deterrent Module	V	V																			V																																		
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V													
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V												
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																		
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																		
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																		
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control	V	V																		V	V																																		
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																		
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
4	2015	Escalade	Powertrain	Drive Motor Control Module 1		V																			V																																		
4	2015	Escalade	Powertrain	Drive Motor Control Module 2		V																			V																																		
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																		
4	2015	Escalade	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V	V						
4	2015	Escalade	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		
4	2015	Escalade	Chassis	Power Steering Control Module	V	V																		V	V																																		
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
4	2015	Escalade	Chassis	Suspension Control Module	V	V																		V	V																																		
4	2015	Escalade	Body	Body Control Module	V	V																		V	V																																		
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
4	2015	Escalade	Body	Passenger Presence Module	V	V																			V																																		
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left	V	V																			V																																		
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right	V	V																			V																																		
4	2015	Escalade	Body	Instrument Cluster	V	V																		V	V																																		
4	2015	Escalade	Body	Radio/HVAC Control	V																				V																																		
4	2015	Escalade	Body	Active Safety Control Module	V	V																		V	V																					V													
4	2015	Escalade	Body	Video Processing Control Module	V	V																		V	V																																		
4	2015	Escalade	Body	Radio	V	V																		V	V																																		
4	2015	Escalade	Body	Amplifier	V	V																			V																																		
4	2015	Escalade	Body	Media Disc Player	V	V																		V	V																																		
4	2015	Escalade	Body	Human Machine Interface Control Module	V	V																		V	V																					V													
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																		
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
4	2015	Escalade	Body	HVAC Control Module	V	V																		V	V																																		
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)	V	V																		V	V																					V													
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)	V	V																			V																					V													
4	2015	Escalade	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																		
4	2015	Escalade	Body	Seat Memory Control Module - Driver	V																																																					
4	2015	Escalade	Body	Keyless Entry Control Module	V	V																		V	V																																		
4	2015	Escalade	Body	Assist Step Control Module	V	V																		V	V																																		
4	2015	Escalade	Body	Left Side Object Detection Control Module	V																			V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
4	2015	Escalade	Body	Parking Assist Control Module	V																		V	V																																				
4	2015	Escalade	Body	Frontview Camera Module	V	V																	V	V																																				
4	2015	Escalade	Body	Steering Column Lock Control Module	V	V																		V																																			
4	2015	Escalade	Body	Battery Energy Control Module		V																		V																																			
4	2015	Escalade	Body	Long Range Radar Sensor Module	V	V																		V																																			
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module	V																			V																																			
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module	V																			V																																			
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module	V																			V																																			
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module	V																			V																																			
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module	V																		V	V				V	V	V	V	V													V														
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																	V	V									V	V	V	V										V													
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																	V	V									V	V	V	V		V																				
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																		V																																			
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control	V	V																	V	V																																			
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control	V	V																	V	V																																			
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive	V	V																	V	V																																			
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																	V	V																																			
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																	V	V																																			
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																	V	V																																			
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V						
4	2015	Escalade ESV	Chassis	Parking Brake Control Module	V	V																		V																						V						V	V	V	V			
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																			
4	2015	Escalade ESV	Chassis	Power Steering Control Module	V	V																	V	V																																			
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module	V																			V																																			
4	2015	Escalade ESV	Chassis	Suspension Control Module	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Body Control Module	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Passenger Presence Module	V	V																		V																																			
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left	V	V																		V																																			
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right	V	V																		V																																			
4	2015	Escalade ESV	Body	Instrument Cluster	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Radio/HVAC Control	V																			V																																			
4	2015	Escalade ESV	Body	Active Safety Control Module	V	V																	V	V																							V											
4	2015	Escalade ESV	Body	Video Processing Control Module	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Radio	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Amplifier	V	V																		V																																			
4	2015	Escalade ESV	Body	Media Disc Player	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Human Machine Interface Control Module	V	V																	V	V																						V											
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																			
4	2015	Escalade ESV	Body	HVAC Control Module	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)	V	V																	V	V																							V											
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)	V	V																		V																							V											
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver	V																																																					
4	2015	Escalade ESV	Body	Keyless Entry Control Module	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Assist Step Control Module	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module	V																		V	V																																			
4	2015	Escalade ESV	Body	Parking Assist Control Module	V																		V	V																																			
4	2015	Escalade ESV	Body	Frontview Camera Module	V	V																	V	V																																			
4	2015	Escalade ESV	Body	Steering Column Lock Control Module	V	V																		V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module	V	V																			V																																			
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module	V																				V																																			
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module	V																				V																																			
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module	V																				V																																			
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module	V																				V																																			
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module	V																		V	V			V	V	V	V	V													V																
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																	V	V									V	V	V	V									V															
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																	V	V									V	V	V	V		V																						
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																	V	V																																				
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																	V	V																																				
4	2016	Escalade	Chassis	Electronic Brake Control Module	V	V																	V	V												V										V	V	V	V	V	V			V				
4	2016	Escalade	Chassis	Parking Brake Control Module	V	V																		V																						V							V	V	V	V		
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																			
4	2016	Escalade	Chassis	Power Steering Control Module	V	V																	V	V																																				
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module	V																			V																																			
4	2016	Escalade	Chassis	Suspension Control Module	V	V																	V	V																																				
4	2016	Escalade	Body	Body Control Module	V	V																	V	V																																				
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																				
4	2016	Escalade	Body	Passenger Presence Module	V	V																		V																																				
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left	V	V																		V																																				
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right	V	V																		V																																				
4	2016	Escalade	Body	Instrument Cluster	V	V																	V	V																																				
4	2016	Escalade	Body	Radio/HVAC Control	V																			V																																			
4	2016	Escalade	Body	Active Safety Control Module	V	V																	V	V																						V														
4	2016	Escalade	Body	Video Processing Control Module	V	V																	V	V																																				
4	2016	Escalade	Body	Radio	V	V																	V	V																																				
4	2016	Escalade	Body	Amplifier	V	V																		V																																				
4	2016	Escalade	Body	Media Disc Player	V	V																	V	V																																				
4	2016	Escalade	Body	Human Machine Interface Control Module	V	V																	V	V																						V														
4	2016	Escalade	Body	Telematics Communication Interface Control Module	V	V																	V	V																																				
4	2016	Escalade	Body	HVAC Control Module	V	V																	V	V																																				
4	2016	Escalade	Body	Liftgate Control Module	V	V																	V	V																						V														
4	2016	Escalade	Body	Seat Memory Control Module - Passenger	V	V																	V	V																																				
4	2016	Escalade	Body	Seat Memory Control Module - Driver	V																																																							
4	2016	Escalade	Body	Keyless Entry Control Module	V	V																	V	V																																				
4	2016	Escalade	Body	Assist Step Control Module	V	V																	V	V																																				
4	2016	Escalade	Body	Left Side Object Detection Control Module	V																		V	V																																				
4	2016	Escalade	Body	Parking Assist Control Module	V																		V	V																																				
4	2016	Escalade	Body	Frontview Camera Module	V	V																	V	V																																				
4	2016	Escalade	Body	Steering Column Lock Control Module	V	V																		V																																				
4	2016	Escalade	Body	Long Range Radar Sensor Module	V	V																		V																																				
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module	V																			V																																				
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module	V																			V																																				
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module	V																			V																																				
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module	V																			V																																				
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module	V																		V	V			V	V	V	V	V													V																
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																	V	V									V	V	V	V									V															
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																	V	V									V	V	V	V		V																						
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																	V	V																																				
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																	V	V																																				
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module	V	V																	V	V												V											V	V	V	V	V	V								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
4	2016	Escalade ESV	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		
4	2016	Escalade ESV	Chassis	Power Steering Control Module	V	V																		V	V																																		
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
4	2016	Escalade ESV	Chassis	Suspension Control Module	V	V																		V	V																																		
4	2016	Escalade ESV	Body	Body Control Module	V	V																		V	V																																		
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
4	2016	Escalade ESV	Body	Passenger Presence Module	V	V																			V																																		
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left	V	V																			V																																		
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right	V	V																			V																																		
4	2016	Escalade ESV	Body	Instrument Cluster	V	V																		V	V																																		
4	2016	Escalade ESV	Body	Radio Control	V																				V																																		
4	2016	Escalade ESV	Body	HVAC Control	V																			V	V																																		
4	2016	Escalade ESV	Body	Active Safety Control Module	V	V																		V	V																					V												
4	2016	Escalade ESV	Body	Video Processing Control Module	V	V																		V	V																																		
4	2016	Escalade ESV	Body	Radio	V	V																		V	V																																		
4	2016	Escalade ESV	Body	Amplifier	V	V																			V																																		
4	2016	Escalade ESV	Body	Media Disc Player	V	V																		V	V																																		
4	2016	Escalade ESV	Body	Human Machine Interface Control Module	V	V																		V	V																					V												
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
4	2016	Escalade ESV	Body	HVAC Control Module	V	V																		V	V																																		
4	2016	Escalade ESV	Body	Liftgate Control Module	V	V																		V	V																					V												
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																		
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver	V																																																					
4	2016	Escalade ESV	Body	Keyless Entry Control Module	V	V																		V	V																																		
4	2016	Escalade ESV	Body	Assist Step Control Module	V	V																		V	V																																		
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module	V																			V	V																																		
4	2016	Escalade ESV	Body	Parking Assist Control Module	V																			V	V																																		
4	2016	Escalade ESV	Body	Frontview Camera Module	V	V																		V	V																																		
4	2016	Escalade ESV	Body	Steering Column Lock Control Module	V	V																			V																																		
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module	V	V																			V																																		
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module	V																				V																																		
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module	V																				V																																		
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module	V																				V																																		
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module	V																				V																																		
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module	V	V							V			V					V			V	V							V														V												
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module	V	V																		V										V	V																							
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module	V	V							V			V					V			V	V							V														V												
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module	V	V																		V										V	V																							
ALL	2004	Hearse	Chassis	DRP/ABS/TCS	V	V																		V																																		
ALL	2004	Hearse	Chassis	Magna Steer	V	V																																																				
ALL	2004	Hearse	Chassis	Rear Integration Module	V	V																		V																																		
ALL	2004	Hearse	Chassis	Tire Pressure Monitor	V	V																																																			
ALL	2004	Hearse	Body	Amplifier (Delco)	V	V																		V																																		
ALL	2004	Hearse	Body	Dash Integration Module	V	V																		V																																		
ALL	2004	Hearse	Body	Driver Door Switch	V	V																																																			
ALL	2004	Hearse	Body	Driver Door Module	V	V																		V																																		
ALL	2004	Hearse	Body	Passenger Door Module	V	V																		V																																		
ALL	2004	Hearse	Body	Instrument Panel Cluster	V	V																		V																																		
ALL	2004	Hearse	Body	Instrument Panel Module	V	V																		V																																		
ALL	2004	Hearse	Body	Personalization																																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
ALL	2004	Hearse	Body	Radio	V	V																		V																																				
ALL	2004	Hearse	Body	Rear Integration Module	V	V																		V																																				
ALL	2004	Hearse	Body	Remote Function Actuation	V	V																																																						
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint	V	V																																																						
ALL	2004	Hearse	Body	Vehicle Theft Deterrent	V	V																																																						
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module	V	V							V			V					V			V	V						V													V															
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module	V	V																		V										V	V																									
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module	V	V							V			V					V			V	V						V													V															
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module	V	V																		V										V	V																									
ALL	2004	Limousine	Chassis	DRP/ABS/TCS	V	V																		V																																				
ALL	2004	Limousine	Chassis	Magna Steer	V	V																																																						
ALL	2004	Limousine	Chassis	Rear Integration Module	V	V																		V																																				
ALL	2004	Limousine	Chassis	Tire Pressure Monitor	V	V																																																						
ALL	2004	Limousine	Body	Amplifier (Delco)	V	V																		V																																				
ALL	2004	Limousine	Body	Dash Integration Module	V	V																		V																																				
ALL	2004	Limousine	Body	Driver Door Switch	V	V																																																						
ALL	2004	Limousine	Body	Driver Door Module	V	V																		V																																				
ALL	2004	Limousine	Body	Passenger Door Module	V	V																		V																																				
ALL	2004	Limousine	Body	Left Mid Door Module	V	V																		V																																				
ALL	2004	Limousine	Body	Left Rear Door Module	V	V																		V																																				
ALL	2004	Limousine	Body	Right Mid Door Module	V	V																		V																																				
ALL	2004	Limousine	Body	Right Rear Door Module	V	V																		V																																				
ALL	2004	Limousine	Body	Instrument Panel Cluster	V	V																		V																																				
ALL	2004	Limousine	Body	Instrument Panel Module	V	V																		V																																				
ALL	2004	Limousine	Body	Memory Seat Module																																																								
ALL	2004	Limousine	Body	Navigation Radio	V	V																																																						
ALL	2004	Limousine	Body	Personalization																																																							
ALL	2004	Limousine	Body	Radio	V	V																		V																																				
ALL	2004	Limousine	Body	Rear Climate Control Panel	V	V																		V																																				
ALL	2004	Limousine	Body	Rear Integration Module	V	V																		V																																				
ALL	2004	Limousine	Body	Remote Function Actuation	V	V																																																						
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint	V	V																																																						
ALL	2004	Limousine	Body	Vehicle Theft Deterrent	V	V																																																						
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module	V	V							V			V					V			V	V						V													V															
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module	V	V																		V										V	V																									
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module	V	V							V			V					V			V	V						V													V															
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module	V	V																		V										V	V																									
ALL	2005	Hearse	Chassis	DRP/ABS/TCS	V	V																		V																																				
ALL	2005	Hearse	Chassis	Magna Steer	V	V																																																						
ALL	2005	Hearse	Chassis	Rear Integration Module	V	V																		V																																				
ALL	2005	Hearse	Chassis	Tire Pressure Monitor	V	V																																																						
ALL	2005	Hearse	Body	Amplifier (Delco)	V	V																		V																																				
ALL	2005	Hearse	Body	Dash Integration Module	V	V																		V																																				
ALL	2005	Hearse	Body	Driver Door Switch	V	V																																																						
ALL	2005	Hearse	Body	Driver Door Module	V	V																		V																																				
ALL	2005	Hearse	Body	Passenger Door Module	V	V																		V																																				
ALL	2005	Hearse	Body	Instrument Panel Cluster	V	V																		V																																				
ALL	2005	Hearse	Body	Instrument Panel Module	V	V																		V																																				
ALL	2005	Hearse	Body	Personalization																																																							
ALL	2005	Hearse	Body	Radio	V	V																		V																																				
ALL	2005	Hearse	Body	Rear Integration Module	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
ALL	2005	Hearse	Body	Remote Function Actuation	V	V																																																							
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint	V	V																																																							
ALL	2005	Hearse	Body	Vehicle Theft Deterrent	V	V																																																							
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module	V	V							V			V					V			V	V							V													V															
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module	V	V																		V											V	V																								
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module	V	V							V			V					V			V	V							V													V															
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module	V	V																		V											V	V																								
ALL	2005	Limousine	Chassis	DRP/ABS/TCS	V	V																		V																																				
ALL	2005	Limousine	Chassis	Magna Steer	V	V																																																						
ALL	2005	Limousine	Chassis	Rear Integration Module	V	V																		V																																				
ALL	2005	Limousine	Chassis	Tire Pressure Monitor	V	V																																																						
ALL	2005	Limousine	Body	Amplifier (Delco)	V	V																		V																																				
ALL	2005	Limousine	Body	Dash Integration Module	V	V																		V																																				
ALL	2005	Limousine	Body	Driver Door Switch	V	V																																																						
ALL	2005	Limousine	Body	Driver Door Module	V	V																		V																																				
ALL	2005	Limousine	Body	Passenger Door Module	V	V																		V																																				
ALL	2005	Limousine	Body	Left Mid Door Module	V	V																		V																																				
ALL	2005	Limousine	Body	Left Rear Door Module	V	V																		V																																				
ALL	2005	Limousine	Body	Right Mid Door Module	V	V																		V																																				
ALL	2005	Limousine	Body	Right Rear Door Module	V	V																		V																																				
ALL	2005	Limousine	Body	Instrument Panel Cluster	V	V																		V																																				
ALL	2005	Limousine	Body	Instrument Panel Module	V	V																		V																																				
ALL	2005	Limousine	Body	Memory Seat Module																																																								
ALL	2005	Limousine	Body	Navigation Radio	V	V																																																						
ALL	2005	Limousine	Body	Personalization																																																							
ALL	2005	Limousine	Body	Radio	V	V																		V																																				
ALL	2005	Limousine	Body	Rear Climate Control Panel	V	V																		V																																				
ALL	2005	Limousine	Body	Rear Integration Module	V	V																		V																																				
ALL	2005	Limousine	Body	Remote Function Actuation	V	V																																																						
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint	V	V																																																						
ALL	2005	Limousine	Body	Vehicle Theft Deterrent	V	V																																																						
ALL	2006	Hearse	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V				V			V													V															
ALL	2006	Hearse	Powertrain	Transmission Control Module	V	V																		V											V	V																								
ALL	2006	Hearse	Chassis	Electronic Brake Control Module	V	V																			V																																			
ALL	2006	Hearse	Chassis	Air Suspension Control Module	V	V																		V	V																																			
ALL	2006	Hearse	Body	Amplifier (Bose)	V	V																		V	V																																			
ALL	2006	Hearse	Body	Body Control Module	V	V																			V																																			
ALL	2006	Hearse	Body	Digital Radio Receiver	V	V																			V																																			
ALL	2006	Hearse	Body	Driver Door Switch	V	V																		V	V																																			
ALL	2006	Hearse	Body	Driver Position Module	V	V																		V	V																																			
ALL	2006	Hearse	Body	HVAC Control Module	V	V																		V	V																																			
ALL	2006	Hearse	Body	Inside Rear View Mirror Module	V																				V																																			
ALL	2006	Hearse	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2006	Hearse	Body	Passenger Door Switch	V	V																		V	V																																			
ALL	2006	Hearse	Body	Passenger Presence System	V	V																			V																																			
ALL	2006	Hearse	Body	Radio	V	V																		V	V																																			
ALL	2006	Hearse	Body	Rear Heated Seat Module	V	V																			V																																			
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint	V	V																			V																																			
ALL	2006	Hearse	Body	Theft Deterrent Module	V	V																			V																																			
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
ALL	2006	Limousine	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V				V			V													V																
ALL	2006	Limousine	Powertrain	Transmission Control Module	V	V																		V											V	V																									
ALL	2006	Limousine	Chassis	Electronic Brake Control Module	V	V																			V																																				
ALL	2006	Limousine	Chassis	Air Suspension Control Module	V	V																		V	V																																			
ALL	2006	Limousine	Body	Amplifier (Bose)	V	V																		V	V																																			
ALL	2006	Limousine	Body	Aux. HVAC Control Module		V																			V																																			
ALL	2006	Limousine	Body	Body Control Module	V	V																			V																																			
ALL	2006	Limousine	Body	Digital Radio Receiver	V	V																			V																																			
ALL	2006	Limousine	Body	Driver Door Switch	V	V																		V	V																																			
ALL	2006	Limousine	Body	Driver Position Module	V	V																		V	V																																			
ALL	2006	Limousine	Body	HVAC Control Module	V	V																		V	V																																			
ALL	2006	Limousine	Body	Inside Rear View Mirror Module	V																				V																																			
ALL	2006	Limousine	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2006	Limousine	Body	Passenger Door Switch	V	V																		V	V																																			
ALL	2006	Limousine	Body	Passenger Presence System	V	V																			V																																			
ALL	2006	Limousine	Body	Radio	V	V																		V	V																																			
ALL	2006	Limousine	Body	Rear Heated Seat Module	V	V																			V																																			
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint	V	V																			V																																			
ALL	2006	Limousine	Body	Theft Deterrent Module	V	V																			V																																			
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
ALL	2007	Hearse	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V				V			V													V																
ALL	2007	Hearse	Powertrain	Transmission Control Module	V	V																		V											V	V																								
ALL	2007	Hearse	Chassis	Air Suspension Control Module	V	V																		V	V																																			
ALL	2007	Hearse	Chassis	Electronic Brake Control Module	V	V																			V																																			
ALL	2007	Hearse	Body	Amplifier (Bose)	V	V																		V	V																																			
ALL	2007	Hearse	Body	Body Control Module	V	V																		V	V																																			
ALL	2007	Hearse	Body	Digital Radio Receiver	V	V																			V																																			
ALL	2007	Hearse	Body	Driver Door Switch	V	V																		V	V																																			
ALL	2007	Hearse	Body	Driver Position Module	V	V																		V	V																																			
ALL	2007	Hearse	Body	HVAC Control Module	V	V																		V	V																																			
ALL	2007	Hearse	Body	Inside Rear View Mirror Module	V																				V																																			
ALL	2007	Hearse	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2007	Hearse	Body	Passenger Door Switch	V	V																		V	V																																			
ALL	2007	Hearse	Body	Passenger Presence System	V	V																			V																																			
ALL	2007	Hearse	Body	Radio	V	V																		V	V																																			
ALL	2007	Hearse	Body	Rear Heated Seat Module	V	V																			V																																			
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint	V	V																			V																																			
ALL	2007	Hearse	Body	Theft Deterrent Module	V	V																			V																																			
ALL	2007	Limousine	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V				V			V													V																
ALL	2007	Limousine	Powertrain	Transmission Control Module	V	V																		V											V	V																								
ALL	2007	Limousine	Chassis	Air Suspension Control Module	V	V																		V	V																																			
ALL	2007	Limousine	Chassis	Electronic Brake Control Module	V	V																			V																																			
ALL	2007	Limousine	Body	Amplifier (Bose)	V	V																		V	V																																			
ALL	2007	Limousine	Body	Aux. HVAC Control Module		V																		V	V																																			
ALL	2007	Limousine	Body	Body Control Module	V	V																		V	V																																			
ALL	2007	Limousine	Body	Digital Radio Receiver	V	V																			V																																			
ALL	2007	Limousine	Body	Driver Door Switch	V	V																		V	V																																			
ALL	2007	Limousine	Body	Driver Position Module	V	V																		V	V																																			
ALL	2007	Limousine	Body	HVAC Control Module	V	V																		V	V																																			
ALL	2007	Limousine	Body	Inside Rear View Mirror Module	V																				V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
ALL	2007	Limousine	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2007	Limousine	Body	Passenger Door Switch	V	V																		V	V																																			
ALL	2007	Limousine	Body	Passenger Presence System	V	V																			V																																			
ALL	2007	Limousine	Body	Radio	V	V																		V	V																																			
ALL	2007	Limousine	Body	Rear Heated Seat Module	V	V																			V																																			
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint	V	V																			V																																			
ALL	2007	Limousine	Body	Theft Deterrent Module	V	V																			V																																			
ALL	2008	Hearse	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V				V			V													V													
ALL	2008	Hearse	Powertrain	Transmission Control Module	V	V																		V											V	V																							
ALL	2008	Hearse	Chassis	Air Suspension Control Module	V	V																		V	V																																			
ALL	2008	Hearse	Chassis	Electronic Brake Control Module	V	V																			V																																			
ALL	2008	Hearse	Body	Amplifier (Bose)	V	V																		V	V																																			
ALL	2008	Hearse	Body	Body Control Module	V	V																		V	V																																			
ALL	2008	Hearse	Body	Climate Control Seat Module	V	V																		V	V																																			
ALL	2008	Hearse	Body	Digital Radio Receiver	V	V																			V																																			
ALL	2008	Hearse	Body	Driver Door Switch	V	V																		V	V																																			
ALL	2008	Hearse	Body	Driver Position Module	V	V																		V	V																																			
ALL	2008	Hearse	Body	HVAC Control Module	V	V																		V	V																																			
ALL	2008	Hearse	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2008	Hearse	Body	Passenger Door Switch	V	V																		V	V																																			
ALL	2008	Hearse	Body	Passenger Presence System	V	V																			V																																			
ALL	2008	Hearse	Body	Radio	V	V																		V	V																																			
ALL	2008	Hearse	Body	Rear Heated Seat Module	V	V																			V																																			
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint	V	V																			V																																			
ALL	2008	Hearse	Body	Theft Deterrent Module	V	V																			V																																			
ALL	2008	Limousine	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V				V			V													V													
ALL	2008	Limousine	Powertrain	Transmission Control Module	V	V																		V											V	V																							
ALL	2008	Limousine	Chassis	Air Suspension Control Module	V	V																		V	V																																			
ALL	2008	Limousine	Chassis	Electronic Brake Control Module	V	V																			V																																			
ALL	2008	Limousine	Body	Amplifier (Bose)	V	V																		V	V																																			
ALL	2008	Limousine	Body	Aux. HVAC Control Module		V																		V	V																																			
ALL	2008	Limousine	Body	Body Control Module	V	V																		V	V																																			
ALL	2008	Limousine	Body	Climate Control Seat Module	V	V																		V	V																																			
ALL	2008	Limousine	Body	Digital Radio Receiver	V	V																			V																																			
ALL	2008	Limousine	Body	Driver Door Switch	V	V																		V	V																																			
ALL	2008	Limousine	Body	Driver Position Module	V	V																		V	V																																			
ALL	2008	Limousine	Body	HVAC Control Module	V	V																		V	V																																			
ALL	2008	Limousine	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2008	Limousine	Body	Passenger Door Switch	V	V																		V	V																																			
ALL	2008	Limousine	Body	Passenger Presence System	V	V																			V																																			
ALL	2008	Limousine	Body	Radio	V	V																		V	V																																			
ALL	2008	Limousine	Body	Rear Heated Seat Module	V	V																			V																																			
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint	V	V																			V																																			
ALL	2008	Limousine	Body	Theft Deterrent Module	V	V																			V																																			
ALL	2009	Hearse	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V				V			V													V													
ALL	2009	Hearse	Powertrain	Transmission Control Module	V	V																		V											V	V																							
ALL	2009	Hearse	Chassis	Air Suspension Control Module	V	V																		V	V																																			
ALL	2009	Hearse	Chassis	Electronic Brake Control Module	V	V																			V																																			
ALL	2009	Hearse	Body	Amplifier (Bose)	V	V																		V	V																																			
ALL	2009	Hearse	Body	Body Control Module	V	V																		V	V																																			
ALL	2009	Hearse	Body	Climate Control Seat Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
ALL	2009	Hearse	Body	Digital Radio Receiver	V	V																		V	V																																				
ALL	2009	Hearse	Body	Driver Door Switch	V	V																		V	V																																				
ALL	2009	Hearse	Body	Driver Position Module	V	V																		V	V																																				
ALL	2009	Hearse	Body	HVAC Control Module	V	V																		V	V																																				
ALL	2009	Hearse	Body	Instrument Panel Cluster	V	V																		V	V																																				
ALL	2009	Hearse	Body	Passenger Door Switch	V	V																		V	V																																				
ALL	2009	Hearse	Body	Passenger Presence System	V	V																			V																																				
ALL	2009	Hearse	Body	Radio	V	V																		V	V																																				
ALL	2009	Hearse	Body	Rear Heated Seat Module	V	V																			V																																				
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint	V	V																			V																																				
ALL	2009	Hearse	Body	Theft Deterrent Module	V	V																			V																																				
ALL	2009	Limousine	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V				V			V														V														
ALL	2009	Limousine	Powertrain	Transmission Control Module	V	V																		V											V	V																								
ALL	2009	Limousine	Chassis	Air Suspension Control Module	V	V																		V	V																																				
ALL	2009	Limousine	Chassis	Electronic Brake Control Module	V	V																			V																																				
ALL	2009	Limousine	Body	Amplifier (Bose)	V	V																		V	V																																				
ALL	2009	Limousine	Body	Aux. HVAC Control Module		V																		V	V																																				
ALL	2009	Limousine	Body	Body Control Module	V	V																		V	V																																				
ALL	2009	Limousine	Body	Climate Control Seat Module	V	V																		V	V																																				
ALL	2009	Limousine	Body	Digital Radio Receiver	V	V																		V	V																																				
ALL	2009	Limousine	Body	Driver Door Switch	V	V																		V	V																																				
ALL	2009	Limousine	Body	Driver Position Module	V	V																		V	V																																				
ALL	2009	Limousine	Body	HVAC Control Module	V	V																		V	V																																				
ALL	2009	Limousine	Body	Instrument Panel Cluster	V	V																		V	V																																				
ALL	2009	Limousine	Body	Passenger Door Switch	V	V																		V	V																																				
ALL	2009	Limousine	Body	Passenger Presence System	V	V																			V																																				
ALL	2009	Limousine	Body	Radio	V	V																		V	V																																				
ALL	2009	Limousine	Body	Rear Heated Seat Module	V	V																			V																																				
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint	V	V																			V																																				
ALL	2009	Limousine	Body	Theft Deterrent Module	V	V																			V																																				
ALL	2010	Hearse	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V				V			V														V														
ALL	2010	Hearse	Powertrain	Transmission Control Module	V	V																		V											V	V																								
ALL	2010	Hearse	Chassis	Air Suspension Control Module	V	V																		V	V																																				
ALL	2010	Hearse	Chassis	Electronic Brake Control Module	V	V																			V																																				
ALL	2010	Hearse	Body	Amplifier (Bose)	V	V																		V	V																																				
ALL	2010	Hearse	Body	Body Control Module	V	V																		V	V																																				
ALL	2010	Hearse	Body	Climate Control Seat Module	V	V																		V	V																																				
ALL	2010	Hearse	Body	Digital Radio Receiver	V	V																		V	V																																				
ALL	2010	Hearse	Body	Driver Door Switch	V	V																		V	V																																				
ALL	2010	Hearse	Body	Driver Position Module	V	V																		V	V																																				
ALL	2010	Hearse	Body	HVAC Control Module	V	V																		V	V																																				
ALL	2010	Hearse	Body	Instrument Panel Cluster	V	V																		V	V																																				
ALL	2010	Hearse	Body	Passenger Door Switch	V	V																		V	V																																				
ALL	2010	Hearse	Body	Passenger Presence System	V	V																			V																																				
ALL	2010	Hearse	Body	Radio	V	V																		V	V																																				
ALL	2010	Hearse	Body	Rear Heated Seat Module	V	V																			V																																				
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint	V	V																			V																																				
ALL	2010	Hearse	Body	Theft Deterrent Module	V	V																			V																																				
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
ALL	2010	Limousine	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V				V			V														V														
ALL	2010	Limousine	Powertrain	Transmission Control Module	V	V																		V											V	V																								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
ALL	2010	Limousine	Chassis	Air Suspension Control Module	V	V																		V	V																																			
ALL	2010	Limousine	Chassis	Electronic Brake Control Module	V	V																			V																																			
ALL	2010	Limousine	Body	Amplifier (Bose)	V	V																		V	V																																			
ALL	2010	Limousine	Body	Aux. HVAC Control Module		V																		V	V																																			
ALL	2010	Limousine	Body	Body Control Module	V	V																		V	V																																			
ALL	2010	Limousine	Body	Climate Control Seat Module	V	V																		V	V																																			
ALL	2010	Limousine	Body	Digital Radio Receiver	V	V																		V	V																																			
ALL	2010	Limousine	Body	Driver Door Switch	V	V																		V	V																																			
ALL	2010	Limousine	Body	Driver Position Module	V	V																		V	V																																			
ALL	2010	Limousine	Body	HVAC Control Module	V	V																		V	V																																			
ALL	2010	Limousine	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2010	Limousine	Body	Passenger Door Switch	V	V																		V	V																																			
ALL	2010	Limousine	Body	Passenger Presence System	V	V																			V																																			
ALL	2010	Limousine	Body	Radio	V	V																		V	V																																			
ALL	2010	Limousine	Body	Rear Heated Seat Module	V	V																			V																																			
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint	V	V																			V																																			
ALL	2010	Limousine	Body	Theft Deterrent Module	V	V																			V																																			
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
ALL	2011	Hearse	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V				V			V														V													
ALL	2011	Hearse	Powertrain	Transmission Control Module	V	V																		V											V	V	V																						
ALL	2011	Hearse	Chassis	Air Suspension Control Module	V	V																		V	V																																			
ALL	2011	Hearse	Chassis	Electronic Brake Control Module	V	V																			V																																			
ALL	2011	Hearse	Body	Amplifier (Bose)	V	V																		V	V																																			
ALL	2011	Hearse	Body	Body Control Module	V	V																		V	V																																			
ALL	2011	Hearse	Body	Climate Control Seat Module	V	V																		V	V																																			
ALL	2011	Hearse	Body	Digital Radio Receiver	V	V																		V	V																																			
ALL	2011	Hearse	Body	Driver Door Switch	V	V																		V	V																																			
ALL	2011	Hearse	Body	Driver Position Module	V	V																		V	V																																			
ALL	2011	Hearse	Body	HVAC Control Module	V	V																		V	V																																			
ALL	2011	Hearse	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2011	Hearse	Body	Passenger Door Switch	V	V																		V	V																																			
ALL	2011	Hearse	Body	Passenger Presence System	V	V																			V																																			
ALL	2011	Hearse	Body	Radio	V	V																		V	V																																			
ALL	2011	Hearse	Body	Rear Heated Seat Module	V	V																			V																																			
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint	V	V																			V																																			
ALL	2011	Hearse	Body	Theft Deterrent Module	V	V																			V																																			
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
ALL	2011	Limousine	Powertrain	Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V				V			V														V													
ALL	2011	Limousine	Powertrain	Transmission Control Module	V	V																		V											V	V	V																						
ALL	2011	Limousine	Chassis	Air Suspension Control Module	V	V																		V	V																																			
ALL	2011	Limousine	Chassis	Electronic Brake Control Module	V	V																			V																																			
ALL	2011	Limousine	Body	Amplifier (Bose)	V	V																		V	V																																			
ALL	2011	Limousine	Body	Aux. HVAC Control Module		V																		V	V																																			
ALL	2011	Limousine	Body	Body Control Module	V	V																		V	V																																			
ALL	2011	Limousine	Body	Climate Control Seat Module	V	V																		V	V																																			
ALL	2011	Limousine	Body	Digital Radio Receiver	V	V																		V	V																																			
ALL	2011	Limousine	Body	Driver Door Switch	V	V																		V	V																																			
ALL	2011	Limousine	Body	Driver Position Module	V	V																		V	V																																			
ALL	2011	Limousine	Body	HVAC Control Module	V	V																		V	V																																			
ALL	2011	Limousine	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2011	Limousine	Body	Passenger Door Switch	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
ALL	2011	Limousine	Body	Passenger Presence System	V	V																			V																																					
ALL	2011	Limousine	Body	Radio	V	V																		V	V																																				
ALL	2011	Limousine	Body	Rear Heated Seat Module	V	V																			V																																					
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint	V	V																			V																																					
ALL	2011	Limousine	Body	Theft Deterrent Module	V	V																			V																																					
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module	V	V																		V	V																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																														V																												
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																									
C	2004	ALL	Body	Driver Door Module																																																									
C	2004	ALL	Body	Driver Seat Module																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Instrument Panel Cluster																																																										
C	2004	ALL	Body	OnStar																																	V																								
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Base Radio																																																										
C	2004	ALL	Body	Uplevel Radio																																																										
C	2004	ALL	Body	Navigation Radio																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																										
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																										
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	ESC																																																									
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2005	ALL	Chassis	VSES																																																									
C	2005	ALL	Body	Amplifier (Bose)																																																										
C	2005	ALL	Body	Body Control Module																														V																												
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																																										
C	2005	ALL	Body	Driver Seat Module																																																										
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2005	ALL	Body	Instrument Panel Cluster																																																										
C	2005	ALL	Body	Passenger Door Module																																																										
C	2005	ALL	Body	Passenger Presence System																																																										
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio																																																										
C	2005	ALL	Body	Rear Aux. Climate Module																																																										
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																																										
C	2005	ALL	Body	Remote Function Actuation																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Body	Vehicle Comm. Interface Module																																	V																									
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	ESC																																																										
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																										
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																															V																											
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																										
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																	V																									
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	ALL	Chassis	Electronic Brake Control Module																																																										
C	2007	ALL	Chassis	Electronic Suspension Control																																																										
C	2007	ALL	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2007	ALL	Body	Assist Step Controller																																																										
C	2007	ALL	Body	Body Control Module																																																										
C	2007	ALL	Body	Body Control Module (aux.)																																																										
C	2007	ALL	Body	Digital Radio Receiver																																																										
C	2007	ALL	Body	Driver Door Switch																																																										
C	2007	ALL	Body	HVAC Control Module																																														V												
C	2007	ALL	Body	Inside Rear View Mirror Module																																																										
C	2007	ALL	Body	Instrument Panel Cluster																																																										
C	2007	ALL	Body	Lift Gate Module																																																										
C	2007	ALL	Body	Memory Seat Module																																																										
C	2007	ALL	Body	Park Assist Module																																																										
C	2007	ALL	Body	Passenger Door Switch																																																										
C	2007	ALL	Body	Passenger Presence System																																																										
C	2007	ALL	Body	Radio																																																										
C	2007	ALL	Body	Rear Heated Seat Module																																																										
C	2007	ALL	Body	Rear HVAC/RSA																																																										
C	2007	ALL	Body	Rollover Sensor																																																										
C	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2007	ALL	Body	Theft Deterrent Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	ALL	Chassis	Electronic Brake Control Module																																																										
C	2008	ALL	Chassis	Electronic Suspension Control																																																										
C	2008	ALL	Chassis	Trailer Brake Control Module																																																										
C	2008	ALL	Body	Amplifier (Bose)																																																										
C	2008	ALL	Body	Assist Step Controller																																																										
C	2008	ALL	Body	Body Control Module																																																										
C	2008	ALL	Body	Body Control Module (aux.)																																																										
C	2008	ALL	Body	Digital Radio Receiver																																																										
C	2008	ALL	Body	Driver Door Switch																																																										
C	2008	ALL	Body	HVAC Control Module																																														V												
C	2008	ALL	Body	Inside Rear View Mirror Module																																																										
C	2008	ALL	Body	Instrument Panel Cluster																																																										
C	2008	ALL	Body	Lift Gate Module																																																										
C	2008	ALL	Body	Memory Seat Module																																																										
C	2008	ALL	Body	Park Assist Module																																																										
C	2008	ALL	Body	Passenger Door Switch																																																										
C	2008	ALL	Body	Passenger Presence System																																																										
C	2008	ALL	Body	Radio																																																										
C	2008	ALL	Body	Rear Heated Seat Module																																																										
C	2008	ALL	Body	Rear HVAC/RSA																																																										
C	2008	ALL	Body	Rollover Sensor																																																										
C	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2008	ALL	Body	Theft Deterrent Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	ALL	Chassis	Electronic Brake Control Module																																																										
C	2009	ALL	Chassis	Electronic Suspension Control																																																										
C	2009	ALL	Chassis	Trailer Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2009	ALL	Body	Amplifier (Bose)																																																								
C	2009	ALL	Body	Assist Step Controller																																																								
C	2009	ALL	Body	Body Control Module																																																								
C	2009	ALL	Body	Body Control Module (aux.)																																																								
C	2009	ALL	Body	Digital Radio Receiver																																																								
C	2009	ALL	Body	Driver Door Switch																																																								
C	2009	ALL	Body	HVAC Control Module																																												V												
C	2009	ALL	Body	Inside Rear View Mirror Module																																																								
C	2009	ALL	Body	Instrument Panel Cluster																																																								
C	2009	ALL	Body	Left Side Object Detection Module																																																								
C	2009	ALL	Body	Lift Gate Module																																																								
C	2009	ALL	Body	Memory Seat Module																																																								
C	2009	ALL	Body	Park Assist Module																																																								
C	2009	ALL	Body	Passenger Door Switch																																																								
C	2009	ALL	Body	Passenger Presence System																																																								
C	2009	ALL	Body	Radio																																																								
C	2009	ALL	Body	Rear Heated Seat Module																																																								
C	2009	ALL	Body	Rear HVAC/RSA																																																								
C	2009	ALL	Body	Right Side Object Detection Module																																																								
C	2009	ALL	Body	Rollover Sensor																																																								
C	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2009	ALL	Body	Theft Deterrent Module																																																								
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																								
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2010	ALL	Chassis	Electronic Brake Control Module																																																								
C	2010	ALL	Chassis	Electronic Suspension Control																																																								
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	ALL	Body	Amplifier (Bose)																																																								
C	2010	ALL	Body	Assist Step Controller																																																								
C	2010	ALL	Body	Body Control Module																																																								
C	2010	ALL	Body	Body Control Module (aux.)																																																								
C	2010	ALL	Body	Digital Radio Receiver																																																								
C	2010	ALL	Body	Driver Door Switch																																																								
C	2010	ALL	Body	HVAC Control Module																																												V												
C	2010	ALL	Body	Inside Rear View Mirror Module																																																								
C	2010	ALL	Body	Instrument Panel Cluster																																																								
C	2010	ALL	Body	Left Side Object Detection Module																																																								
C	2010	ALL	Body	Lift Gate Module																																																								
C	2010	ALL	Body	Memory Seat Module																																																								
C	2010	ALL	Body	Park Assist Module																																																								
C	2010	ALL	Body	Passenger Door Switch																																																								
C	2010	ALL	Body	Passenger Presence System																																																								
C	2010	ALL	Body	Radio																																																								
C	2010	ALL	Body	Rear Heated Seat Module																																																								
C	2010	ALL	Body	Rear HVAC/RSA																																																								
C	2010	ALL	Body	Right Side Object Detection Module																																																								
C	2010	ALL	Body	Supplemental Inflatable Restraint																									V	V																														

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2010	ALL	Body	Theft Deterrent Module																																																								
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																								
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																																								
E	2004	ALL	Chassis	Electronic Suspension Control																																																								
E	2004	ALL	Chassis	Tire Pressure Monitor																																																								
E	2004	ALL	Chassis	VES																																																								
E	2004	ALL	Body	Amplifier (Bose)																																																								
E	2004	ALL	Body	Amplifier (Delco)																																																								
E	2004	ALL	Body	Climate Control Panel																																											V													
E	2004	ALL	Body	Dash Integration Module																																																								
E	2004	ALL	Body	Disc Player and Video Display																																																								
E	2004	ALL	Body	Driver Door Switch																																																								
E	2004	ALL	Body	Driver Door Module																																																								
E	2004	ALL	Body	Passenger Door Module																																																								
E	2004	ALL	Body	Left Rear Door Module																																																								
E	2004	ALL	Body	Right Rear Door Module																																																								
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																								
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																								
E	2004	ALL	Body	Instrument Panel Cluster																																																								
E	2004	ALL	Body	Memory Seat Module																																																								
E	2004	ALL	Body	OnStar																																V																								
E	2004	ALL	Body	Personalization																																																								
E	2004	ALL	Body	Base Radio																																																								
E	2004	ALL	Body	Navigation Radio																																																								
E	2004	ALL	Body	Rear Integration Module																																																								
E	2004	ALL	Body	Rear Seat Module																																																								
E	2004	ALL	Body	Remote Function Actuation																																																								
E	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
E	2004	ALL	Body	TV Antenna Module																																																								
E	2004	ALL	Body	Vehicle Theft Deterrent																																																								
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																								
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																																								
E	2005	ALL	Chassis	Electronic Suspension Control																																																								
E	2005	ALL	Chassis	Tire Pressure Monitor																																																								
E	2005	ALL	Chassis	VES																																																								
E	2005	ALL	Body	Amplifier (Bose)																																																								
E	2005	ALL	Body	Amplifier (Delco)																																																								
E	2005	ALL	Body	Climate Control Panel																																											V													
E	2005	ALL	Body	Dash Integration Module																																																								
E	2005	ALL	Body	Disc Player and Video Display																																																								
E	2005	ALL	Body	Driver Door Switch																																																								
E	2005	ALL	Body	Driver Door Module																																																								
E	2005	ALL	Body	Passenger Door Module																																																								
E	2005	ALL	Body	Left Rear Door Module																																																								
E	2005	ALL	Body	Right Rear Door Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2005	ALL	Body	Instrument Panel Cluster																																																										
E	2005	ALL	Body	Memory Seat Module																																																										
E	2005	ALL	Body	Personalization																																																										
E	2005	ALL	Body	Base Radio																																																										
E	2005	ALL	Body	Navigation Radio																																																										
E	2005	ALL	Body	Rear Integration Module																																																										
E	2005	ALL	Body	Rear Seat Module																																																										
E	2005	ALL	Body	Remote Function Actuation																																																										
E	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2005	ALL	Body	TV Antenna Module																																																										
E	2005	ALL	Body	Vehicle Comm. Interface Module																																	V																									
E	2005	ALL	Body	Vehicle Theft Deterrent																																																										
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																										
E	2006	ALL	Chassis	Electronic Suspension Control																																																										
E	2006	ALL	Chassis	Tire Pressure Monitor																																																										
E	2006	ALL	Chassis	VES																																																										
E	2006	ALL	Body	Amplifier (Bose)																																																										
E	2006	ALL	Body	Amplifier (Delco)																																																										
E	2006	ALL	Body	Climate Control Panel																																											V															
E	2006	ALL	Body	Dash Integration Module																																																										
E	2006	ALL	Body	Disc Player and Video Display																																																										
E	2006	ALL	Body	Driver Door Switch																																																										
E	2006	ALL	Body	Driver Door Module																																																										
E	2006	ALL	Body	Passenger Door Module																																																										
E	2006	ALL	Body	Left Rear Door Module																																																										
E	2006	ALL	Body	Right Rear Door Module																																																										
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2006	ALL	Body	Instrument Panel Cluster																																																										
E	2006	ALL	Body	Lift Gate Module																																																										
E	2006	ALL	Body	Memory Seat Module																																																										
E	2006	ALL	Body	Personalization																																																										
E	2006	ALL	Body	Base Radio																																																										
E	2006	ALL	Body	Navigation Radio																																																										
E	2006	ALL	Body	Rear Integration Module																																																										
E	2006	ALL	Body	Rear Seat Module																																																										
E	2006	ALL	Body	Remote Function Actuation																																																										
E	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2006	ALL	Body	Vehicle Comm. Interface Module																																	V																									
E	2006	ALL	Body	Vehicle Theft Deterrent																																																										
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2007	ALL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
E	2007	ALL	Chassis	Electronic Suspension Control																																																								
E	2007	ALL	Body	Amplifier (Bose)																																																								
E	2007	ALL	Body	Body Control Module																																																								
E	2007	ALL	Body	Body Control Module (aux.)																																																								
E	2007	ALL	Body	Digital Radio Receiver																																																								
E	2007	ALL	Body	Driver Door Switch																																																								
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																								
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																								
E	2007	ALL	Body	HVAC Control Module																																												V												
E	2007	ALL	Body	Instrument Panel Cluster																																																								
E	2007	ALL	Body	Lift Gate Module																																																								
E	2007	ALL	Body	Memory Seat Module																																																								
E	2007	ALL	Body	Park Assist Module																																																								
E	2007	ALL	Body	Passenger Door Switch																																																								
E	2007	ALL	Body	Passenger Presence System																																																								
E	2007	ALL	Body	Radio																																																								
E	2007	ALL	Body	Rear HVAC/RSA																																																								
E	2007	ALL	Body	Rear Seat Module																																																								
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																								
E	2007	ALL	Body	Rollover Sensor																																																								
E	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
E	2007	ALL	Body	Theft Deterrent Module																																																								
E	2007	ALL	Body	TV Antenna Module																																																								
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																								
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
E	2008	ALL	Chassis	Electronic Brake Control Module																																																								
E	2008	ALL	Chassis	Electronic Suspension Control																																																								
E	2008	ALL	Body	Amplifier (Bose)																																																								
E	2008	ALL	Body	Body Control Module																																																								
E	2008	ALL	Body	Body Control Module (aux.)																																																								
E	2008	ALL	Body	Digital Radio Receiver																																																								
E	2008	ALL	Body	Driver Door Switch																																																								
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																								
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																								
E	2008	ALL	Body	HVAC Control Module																																												V												
E	2008	ALL	Body	Instrument Panel Cluster																																																								
E	2008	ALL	Body	Lift Gate Module																																																								
E	2008	ALL	Body	Memory Seat Module																																																								
E	2008	ALL	Body	Park Assist Module																																																								
E	2008	ALL	Body	Passenger Door Switch																																																								
E	2008	ALL	Body	Passenger Presence System																																																								
E	2008	ALL	Body	Radio																																																								
E	2008	ALL	Body	Rear HVAC/RSA																																																								
E	2008	ALL	Body	Rear Seat Module																																																								
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
E	2008	ALL	Body	Rollover Sensor																																																								
E	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
E	2008	ALL	Body	Theft Deterrent Module																																																								
E	2008	ALL	Body	TV Antenna Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																								
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
E	2009	ALL	Chassis	Electronic Brake Control Module																																																								
E	2009	ALL	Chassis	Electronic Suspension Control																																																								
E	2009	ALL	Body	Amplifier (Bose)																																																								
E	2009	ALL	Body	Body Control Module																																																								
E	2009	ALL	Body	Body Control Module (aux.)																																																								
E	2009	ALL	Body	Digital Radio Receiver																																																								
E	2009	ALL	Body	Driver Door Switch																																																								
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																								
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																								
E	2009	ALL	Body	HVAC Control Module																																																								
E	2009	ALL	Body	Instrument Panel Cluster																																																								
E	2009	ALL	Body	Lift Gate Module																																																								
E	2009	ALL	Body	Memory Seat Module																																																								
E	2009	ALL	Body	Park Assist Module																																																								
E	2009	ALL	Body	Passenger Door Switch																																																								
E	2009	ALL	Body	Passenger Presence System																																																								
E	2009	ALL	Body	Radio																																																								
E	2009	ALL	Body	Rear HVAC/RSA																																																								
E	2009	ALL	Body	Rear Seat Module																																																								
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																								
E	2009	ALL	Body	Rollover Sensor																																																								
E	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
E	2009	ALL	Body	Theft Deterrent Module																																																								
E	2009	ALL	Body	TV Antenna Module																																																								
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																								
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																								
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																								
K	2004	ALL	Chassis	ESC																																																								
K	2004	ALL	Chassis	Rear Wheel Steering																																																								
K	2004	ALL	Chassis	Tire Pressure Monitor																																																								
K	2004	ALL	Chassis	VSES																																																								
K	2004	ALL	Body	Amplifier (Bose)																																																								
K	2004	ALL	Body	Body Control Module																														V																										
K	2004	ALL	Body	CD Changer																																																								
K	2004	ALL	Body	Chime																																																								
K	2004	ALL	Body	Driver Door Module																																																								
K	2004	ALL	Body	Driver Seat Module																																																								
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																								
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																								
K	2004	ALL	Body	Instrument Panel Cluster																																																								
K	2004	ALL	Body	OnStar																															V																									
K	2004	ALL	Body	Passenger Door Module																																																								
K	2004	ALL	Body	Passenger Presence System																																																								
K	2004	ALL	Body	Base Radio																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2004	ALL	Body	Uplevel Radio																																																									
K	2004	ALL	Body	Navigation Radio																																																									
K	2004	ALL	Body	Rear Aux. Climate Module																																																									
K	2004	ALL	Body	Rear HVAC																																																									
K	2004	ALL	Body	Rear Seat Audio																																																									
K	2004	ALL	Body	Rear Seat Entertainment																																																									
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																									
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																									
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2005	ALL	Chassis	ESC																																																								
K	2005	ALL	Chassis	Rear Wheel Steering																																																									
K	2005	ALL	Chassis	Tire Pressure Monitor																																																									
K	2005	ALL	Chassis	VSES																																																									
K	2005	ALL	Body	Amplifier (Bose)																																																									
K	2005	ALL	Body	Body Control Module																														V																												
K	2005	ALL	Body	CD Changer																																																									
K	2005	ALL	Body	Chime																																																									
K	2005	ALL	Body	Disc Player and Video Display																																																									
K	2005	ALL	Body	Driver Door Module																																																									
K	2005	ALL	Body	Driver Seat Module																																																									
K	2005	ALL	Body	Generator Battery Control Module																																																									
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																									
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2005	ALL	Body	Instrument Panel Cluster																																																									
K	2005	ALL	Body	Passenger Door Module																																																									
K	2005	ALL	Body	Passenger Presence System																																																									
K	2005	ALL	Body	Base Radio																																																									
K	2005	ALL	Body	Uplevel Radio																																																									
K	2005	ALL	Body	Navigation Radio																																																									
K	2005	ALL	Body	Rear Aux. Climate Module																																																									
K	2005	ALL	Body	Rear HVAC																																																									
K	2005	ALL	Body	Rear Seat Audio																																																									
K	2005	ALL	Body	Remote Function Actuation																																																									
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2005	ALL	Body	Vehicle Comm. Interface Module																																	V																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																									
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																									
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2006	ALL	Chassis	ESC																																																								
K	2006	ALL	Chassis	Tire Pressure Monitor																																																									
K	2006	ALL	Chassis	VSES																																																									
K	2006	ALL	Body	Amplifier (Bose)																																																									
K	2006	ALL	Body	Body Control Module																														V																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2006	ALL	Body	CD Changer																																																										
K	2006	ALL	Body	Chime																																																										
K	2006	ALL	Body	Disc Player and Video Display																																																										
K	2006	ALL	Body	Driver Door Module																																																										
K	2006	ALL	Body	Driver Seat Module																																																										
K	2006	ALL	Body	Generator Battery Control Module																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2006	ALL	Body	Instrument Panel Cluster																																																										
K	2006	ALL	Body	Passenger Door Module																																																										
K	2006	ALL	Body	Passenger Presence System																																																										
K	2006	ALL	Body	Base Radio																																																										
K	2006	ALL	Body	Uplevel Radio																																																										
K	2006	ALL	Body	Navigation Radio																																																										
K	2006	ALL	Body	Rear Aux. Climate Module																																																										
K	2006	ALL	Body	Rear HVAC																																																										
K	2006	ALL	Body	Rear Seat Audio																																																										
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2006	ALL	Body	Vehicle Comm. Interface Module																																	V																									
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2007	ALL	Chassis	Electronic Brake Control Module																																																										
K	2007	ALL	Chassis	Electronic Suspension Control																																																										
K	2007	ALL	Body	Amplifier (Bose)																																																										
K	2007	ALL	Body	Assist Step Controller																																																										
K	2007	ALL	Body	Body Control Module																																																										
K	2007	ALL	Body	Body Control Module (aux.)																																																										
K	2007	ALL	Body	Digital Radio Receiver																																																										
K	2007	ALL	Body	Driver Door Switch																																																										
K	2007	ALL	Body	HVAC Control Module																																										V																
K	2007	ALL	Body	Inside Rear View Mirror Module																																																										
K	2007	ALL	Body	Instrument Panel Cluster																																																										
K	2007	ALL	Body	Lift Gate Module																																																										
K	2007	ALL	Body	Memory Seat Module																																																										
K	2007	ALL	Body	Park Assist Module																																																										
K	2007	ALL	Body	Passenger Door Switch																																																										
K	2007	ALL	Body	Passenger Presence System																																																										
K	2007	ALL	Body	Radio																																																										
K	2007	ALL	Body	Rear Heated Seat Module																																																										
K	2007	ALL	Body	Rear HVAC/RSA																																																										
K	2007	ALL	Body	Rollover Sensor																																																										
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2007	ALL	Body	Theft Deterrent Module																																																										
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	ALL	Chassis	Electronic Brake Control Module																																																										
K	2008	ALL	Chassis	Electronic Suspension Control																																																										
K	2008	ALL	Chassis	Trailer Brake Control Module																																																										
K	2008	ALL	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2008	ALL	Body	Assist Step Controller																																																								
K	2008	ALL	Body	Body Control Module																																																								
K	2008	ALL	Body	Body Control Module (aux.)																																																								
K	2008	ALL	Body	Digital Radio Receiver																																																								
K	2008	ALL	Body	Driver Door Switch																																																								
K	2008	ALL	Body	HVAC Control Module																																																								
K	2008	ALL	Body	Inside Rear View Mirror Module																																																								
K	2008	ALL	Body	Instrument Panel Cluster																																																								
K	2008	ALL	Body	Lift Gate Module																																																								
K	2008	ALL	Body	Memory Seat Module																																																								
K	2008	ALL	Body	Park Assist Module																																																								
K	2008	ALL	Body	Passenger Door Switch																																																								
K	2008	ALL	Body	Passenger Presence System																																																								
K	2008	ALL	Body	Radio																																																								
K	2008	ALL	Body	Rear Heated Seat Module																																																								
K	2008	ALL	Body	Rear HVAC/RSA																																																								
K	2008	ALL	Body	Rollover Sensor																																																								
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2008	ALL	Body	Theft Deterrent Module																																																								
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2009	ALL	Chassis	Electronic Brake Control Module																																																								
K	2009	ALL	Chassis	Electronic Suspension Control																																																								
K	2009	ALL	Chassis	Trailer Brake Control Module																																																								
K	2009	ALL	Body	Amplifier (Bose)																																																								
K	2009	ALL	Body	Assist Step Controller																																																								
K	2009	ALL	Body	Body Control Module																																																								
K	2009	ALL	Body	Body Control Module (aux.)																																																								
K	2009	ALL	Body	Digital Radio Receiver																																																								
K	2009	ALL	Body	Driver Door Switch																																																								
K	2009	ALL	Body	HVAC Control Module																																																								
K	2009	ALL	Body	Inside Rear View Mirror Module																																																								
K	2009	ALL	Body	Instrument Panel Cluster																																																								
K	2009	ALL	Body	Left Side Object Detection Module																																																								
K	2009	ALL	Body	Lift Gate Module																																																								
K	2009	ALL	Body	Memory Seat Module																																																								
K	2009	ALL	Body	Park Assist Module																																																								
K	2009	ALL	Body	Passenger Door Switch																																																								
K	2009	ALL	Body	Passenger Presence System																																																								
K	2009	ALL	Body	Radio																																																								
K	2009	ALL	Body	Rear Heated Seat Module																																																								
K	2009	ALL	Body	Rear HVAC/RSA																																																								
K	2009	ALL	Body	Right Side Object Detection Module																																																								
K	2009	ALL	Body	Rollover Sensor																																																								
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2009	ALL	Body	Theft Deterrent Module																																																								
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																								
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	ALL	Chassis	Electronic Brake Control Module																																																										
K	2010	ALL	Chassis	Electronic Suspension Control																																																										
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	ALL	Body	Amplifier (Bose)																																																										
K	2010	ALL	Body	Assist Step Controller																																																										
K	2010	ALL	Body	Body Control Module																																																										
K	2010	ALL	Body	Body Control Module (aux.)																																																										
K	2010	ALL	Body	Digital Radio Receiver																																																										
K	2010	ALL	Body	Driver Door Switch																																																										
K	2010	ALL	Body	HVAC Control Module																																																										
K	2010	ALL	Body	Inside Rear View Mirror Module																																																										
K	2010	ALL	Body	Instrument Panel Cluster																																																										
K	2010	ALL	Body	Left Side Object Detection Module																																																										
K	2010	ALL	Body	Lift Gate Module																																																										
K	2010	ALL	Body	Memory Seat Module																																																										
K	2010	ALL	Body	Park Assist Module																																																										
K	2010	ALL	Body	Passenger Door Switch																																																										
K	2010	ALL	Body	Passenger Presence System																																																										
K	2010	ALL	Body	Radio																																																										
K	2010	ALL	Body	Rear Heated Seat Module																																																										
K	2010	ALL	Body	Rear HVAC/RSA																																																										
K	2010	ALL	Body	Right Side Object Detection Module																																																										
K	2010	ALL	Body	Supplemental Inflatable Restraint																									V	V																																
K	2010	ALL	Body	Theft Deterrent Module																																																										
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																										
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																										
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																	V	V								
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2010	SRX	Chassis	Electronic Brake Control Module					V																																																					
N	2010	SRX	Chassis	Parking Brake Control Module																																																										
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
N	2010	SRX	Chassis	Suspension Control Module																																																										
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V																																			
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V																																			
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
N	2010	SRX	Body	Passenger Presence Module																															V																											
N	2010	SRX	Body	Instrument Cluster																																V																										
N	2010	SRX	Body	Headlamp Control Module																																																										
N	2010	SRX	Body	Trailer Interface Control Module																																V																										
N	2010	SRX	Body	Radio																																																										
N	2010	SRX	Body	Rear Audio Control Module																																																										
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2010	SRX	Body	Multimedia Player Interface Module																																V																										
N	2010	SRX	Body	Mobile Telephone Control Module																																V																										
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																	V	V	V	V																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Reset	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																						
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V	V	V	V									
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																														V												V	V	V	V	V									
N	2010	SRX	Body	Liftgate Control Module																																																								
N	2010	SRX	Body	Seat Memory Control Module																																					V	V																		
N	2010	SRX	Body	Front Seat Heating Control Module																																					V	V																		
N	2010	SRX	Body	Rear Seat Heating Control Module																																							V	V																
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																							
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																							
N	2010	SRX	Body	Parking Assist Control Module																																V																								
N	2010	SRX	Body	Steering Column Lock Control Module																																																							
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																							
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																							
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																	V	V					
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																				V																																			
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																							
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																						
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																						
N	2011	SRX	Chassis	Electronic Brake Control Module					V																																																	
N	2011	SRX	Chassis	Parking Brake Control Module																																																						
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																						
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
N	2011	SRX	Chassis	Suspension Control Module																																																						
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V		V		V	V	V	V	V	V	V	V	V																								V						
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V		V		V	V	V	V	V	V	V	V	V																								V						
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
N	2011	SRX	Body	Passenger Presence Module																																V																							
N	2011	SRX	Body	Instrument Cluster																																	V																						
N	2011	SRX	Body	Headlamp Control Module																																																						
N	2011	SRX	Body	Trailer Interface Control Module																																	V																						
N	2011	SRX	Body	Radio																																																						
N	2011	SRX	Body	Rear Audio Control Module																																																						
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																						
N	2011	SRX	Body	Multimedia Player Interface Module																																	V																						
N	2011	SRX	Body	Mobile Telephone Control Module																																	V																						
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V	V	V	V									
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																														V												V	V	V	V	V									
N	2011	SRX	Body	Liftgate Control Module																																																						
N	2011	SRX	Body	Seat Memory Control Module																																																						
N	2011	SRX	Body	Front Seat Heating Control Module																																					V	V																		
N	2011	SRX	Body	Rear Seat Heating Control Module																																							V	V																
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																						
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																						
N	2011	SRX	Body	Parking Assist Control Module																																	V																						
N	2011	SRX	Body	Steering Column Lock Control Module																																																						
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																			
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																						
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																						
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																			

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																									
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2012	SRX	Chassis	Electronic Brake Control Module					V																																																				
N	2012	SRX	Chassis	Parking Brake Control Module																																																									
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
N	2012	SRX	Chassis	Suspension Control Module																																																									
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V		V		V	V	V	V	V	V	V	V																								V								
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V		V		V	V	V	V	V	V	V	V																								V								
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
N	2012	SRX	Body	Passenger Presence Module																																V																										
N	2012	SRX	Body	Instrument Cluster																																	V																								
N	2012	SRX	Body	Headlamp Control Module																																																									
N	2012	SRX	Body	Trailer Interface Control Module																																	V																								
N	2012	SRX	Body	Radio																																																									
N	2012	SRX	Body	Rear Audio Control Module																																																									
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																									
N	2012	SRX	Body	Multimedia Player Interface Module																																	V																								
N	2012	SRX	Body	Mobile Telephone Control Module																																	V																								
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																			
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																														V													V	V	V	V	V							
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																														V													V	V	V	V	V							
N	2012	SRX	Body	Liftgate Control Module																																																									
N	2012	SRX	Body	Seat Memory Control Module																																																									
N	2012	SRX	Body	Front Seat Heating Control Module																																						V	V																			
N	2012	SRX	Body	Rear Seat Heating Control Module																																								V	V																
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																									
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
N	2012	SRX	Body	Parking Assist Control Module																																	V																								
N	2012	SRX	Body	Steering Column Lock Control Module																																																									
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																					
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																					
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2013	SRX	Chassis	Electronic Brake Control Module					V																																																				
N	2013	SRX	Chassis	Parking Brake Control Module																																																									
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
N	2013	SRX	Chassis	Suspension Control Module																																																									
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V	V	V	V	V	V		V		V	V	V	V	V	V	V	V																								V								
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V	V	V	V	V	V		V		V	V	V	V	V	V	V	V																								V								
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
N	2013	SRX	Body	Passenger Presence Module																																V																										
N	2013	SRX	Body	Instrument Cluster																																	V																								
N	2013	SRX	Body	Radio/HVAC Control																																																									
N	2013	SRX	Body	Active Safety Control Module																																																									
N	2013	SRX	Body	Headlamp Control Module																																																									
N	2013	SRX	Body	Trailer Interface Control Module																																	V																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
N	2013	SRX	Body	Radio																																																								
N	2013	SRX	Body	Amplifier																																																								
N	2013	SRX	Body	Media Disc Player																																																								
N	2013	SRX	Body	Human Machine Interface Control Module																																																								
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																														V													V	V	V	V	V									
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																														V													V	V	V	V	V									
N	2013	SRX	Body	Liftgate Control Module																																																								
N	2013	SRX	Body	Seat Memory Control Module																																																								
N	2013	SRX	Body	Rear Seat Heating Control Module																																							V	V																
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																								
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																								
N	2013	SRX	Body	Right Side Object Detection Control Module																																																								
N	2013	SRX	Body	Left Side Object Detection Control Module																																																								
N	2013	SRX	Body	Parking Assist Control Module																																V																								
N	2013	SRX	Body	Frontview Camera Module																																																								
N	2013	SRX	Body	Steering Column Lock Control Module																																																								
N	2013	SRX	Body	Long Range Radar Sensor Module																																																								
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																								
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																								
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																								
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																				
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																								
N	2014	SRX	Chassis	Electronic Brake Control Module					V																																																			
N	2014	SRX	Chassis	Parking Brake Control Module																																																								
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																								
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
N	2014	SRX	Chassis	Suspension Control Module																																																								
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																										V						
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																										V						
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
N	2014	SRX	Body	Passenger Presence Module																															V																									
N	2014	SRX	Body	Instrument Cluster																																V																								
N	2014	SRX	Body	Radio/HVAC Control																																																								
N	2014	SRX	Body	Active Safety Control Module																																																								
N	2014	SRX	Body	Headlamp Control Module																																																								
N	2014	SRX	Body	Trailer Interface Control Module																																V																								
N	2014	SRX	Body	Radio																																																								
N	2014	SRX	Body	Amplifier																																																								
N	2014	SRX	Body	Media Disc Player																																																								
N	2014	SRX	Body	Human Machine Interface Control Module																																																								
N	2014	SRX	Body	Navigation Control Module																																																								
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																V	V	V																						
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																														V													V	V	V	V	V									
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																														V													V	V	V	V	V									
N	2014	SRX	Body	Liftgate Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																								
N	2014	SRX	Body	Rear Seat Heating Control Module																																							V	V																
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																							
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																							
N	2014	SRX	Body	Right Side Object Detection Control Module																																																							
N	2014	SRX	Body	Left Side Object Detection Control Module																																																							
N	2014	SRX	Body	Parking Assist Control Module																																V																							
N	2014	SRX	Body	Frontview Camera Module																																																						
N	2014	SRX	Body	Steering Column Lock Control Module																																																						
N	2014	SRX	Body	Long Range Radar Sensor Module																																																						
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																						
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																						
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																						
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																			
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																						
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																			
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																						
N	2015	SRX	Chassis	Electronic Brake Control Module					V																																																	
N	2015	SRX	Chassis	Parking Brake Control Module																																																						
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																						
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
N	2015	SRX	Chassis	Suspension Control Module																																																						
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																								V						
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																								V						
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
N	2015	SRX	Body	Passenger Presence Module																																V																							
N	2015	SRX	Body	Instrument Cluster																																	V																						
N	2015	SRX	Body	Radio/HVAC Control																																																						
N	2015	SRX	Body	Active Safety Control Module																																																						
N	2015	SRX	Body	Headlamp Control Module																																																						
N	2015	SRX	Body	Trailer Interface Control Module																																	V																						
N	2015	SRX	Body	Radio																																																						
N	2015	SRX	Body	Amplifier																																																						
N	2015	SRX	Body	Rear Audio Control Module																																																						
N	2015	SRX	Body	Media Disc Player																																																						
N	2015	SRX	Body	Human Machine Interface Control Module																																																						
N	2015	SRX	Body	Navigation Control Module																																																						
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V	V	V	V								
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																														V												V	V	V	V	V								
N	2015	SRX	Body	Liftgate Control Module																																																						
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																						
N	2015	SRX	Body	Rear Seat Heating Control Module																																							V	V															
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																						
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																						
N	2015	SRX	Body	Right Side Object Detection Control Module																																																						
N	2015	SRX	Body	Left Side Object Detection Control Module																																																						
N	2015	SRX	Body	Parking Assist Control Module																																V																						
N	2015	SRX	Body	Frontview Camera Module																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
N	2015	SRX	Body	Steering Column Lock Control Module																																																											
N	2015	SRX	Body	Long Range Radar Sensor Module																																																											
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																											
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																							
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																							
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2016	SRX	Chassis	Electronic Brake Control Module					V																																																						
N	2016	SRX	Chassis	Parking Brake Control Module																																																											
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module				V	V																																																						
N	2016	SRX	Chassis	Suspension Control Module																																																											
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																										V								
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)						V	V	V		V	V	V	V		V		V	V	V	V	V	V	V	V																										V								
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
N	2016	SRX	Body	Passenger Presence Module																																V																											
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																	V																									
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																	V																									
N	2016	SRX	Body	Radio/HVAC Control																																																										
N	2016	SRX	Body	Active Safety Control Module																																																										
N	2016	SRX	Body	Headlamp Control Module																																																										
N	2016	SRX	Body	Trailer Interface Control Module																																	V																									
N	2016	SRX	Body	Radio																																																										
N	2016	SRX	Body	Amplifier																																																										
N	2016	SRX	Body	Rear Audio Control Module																																																										
N	2016	SRX	Body	Media Disc Player																																																										
N	2016	SRX	Body	Human Machine Interface Control Module																																																										
N	2016	SRX	Body	Navigation Control Module																																																										
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																							
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																							
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																														V													V	V	V	V	V									
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																														V													V	V	V	V	V									
N	2016	SRX	Body	Liftgate Control Module																																																										
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2016	SRX	Body	Rear Seat Heating Control Module																																							V	V																		
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2016	SRX	Body	Right Side Object Detection Control Module																																																										
N	2016	SRX	Body	Left Side Object Detection Control Module																																																										
N	2016	SRX	Body	Parking Assist Control Module																																	V																									
N	2016	SRX	Body	Frontview Camera Module																																																										
N	2016	SRX	Body	Steering Column Lock Control Module																																																										
N	2016	SRX	Body	Long Range Radar Sensor Module																																																										
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																										
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
3	2011	ALL	Chassis	Electronic Brake Control Module																																																												
3	2011	ALL	Chassis	Electronic Suspension Control																																																												
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																												
3	2011	ALL	Body	Amplifier (Bose)																																																												
3	2011	ALL	Body	Assist Step Controller																																																												
3	2011	ALL	Body	Body Control Module																																																												
3	2011	ALL	Body	Body Control Module (aux.)																																																												
3	2011	ALL	Body	Digital Radio Receiver																																																												
3	2011	ALL	Body	Driver Door Switch																																																												
3	2011	ALL	Body	HVAC Control Module																																												V																
3	2011	ALL	Body	Inside Rear View Mirror Module																																																												
3	2011	ALL	Body	Instrument Panel Cluster																																																												
3	2011	ALL	Body	Left Side Object Detection Module																																																												
3	2011	ALL	Body	Lift Gate Module																																																												
3	2011	ALL	Body	Memory Seat Module																																																												
3	2011	ALL	Body	Park Assist Module																																																												
3	2011	ALL	Body	Passenger Door Switch																																																												
3	2011	ALL	Body	Passenger Presence System																																																												
3	2011	ALL	Body	Radio																																																												
3	2011	ALL	Body	Rear Heated Seat Module																																																												
3	2011	ALL	Body	Rear HVAC/RSA																																																												
3	2011	ALL	Body	Right Side Object Detection Module																																																												
3	2011	ALL	Body	Supplemental Inflatable Restraint																								V	V																																		
3	2011	ALL	Body	Theft Deterrent Module																																																												
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
3	2012	ALL	Chassis	Electronic Brake Control Module																																																												
3	2012	ALL	Chassis	Electronic Suspension Control																																																												
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																												
3	2012	ALL	Body	Amplifier (Bose)																																																												
3	2012	ALL	Body	Assist Step Controller																																																												
3	2012	ALL	Body	Body Control Module																																																												
3	2012	ALL	Body	Body Control Module (aux.)																																																												
3	2012	ALL	Body	Driver Door Switch																																																												
3	2012	ALL	Body	HVAC Control Module																																												V																
3	2012	ALL	Body	Inside Rear View Mirror Module																																																												
3	2012	ALL	Body	Instrument Panel Cluster																																																												
3	2012	ALL	Body	Left Side Object Detection Module																																																												
3	2012	ALL	Body	Lift Gate Module																																																												
3	2012	ALL	Body	Memory Seat Module																																																												
3	2012	ALL	Body	Park Assist Module																																																												
3	2012	ALL	Body	Passenger Door Switch																																																												
3	2012	ALL	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
3	2012	ALL	Body	Radio																																																								
3	2012	ALL	Body	Rear Heated Seat Module																																																								
3	2012	ALL	Body	Rear HVAC/RSA																																																								
3	2012	ALL	Body	Right Side Object Detection Module																																																								
3	2012	ALL	Body	Supplemental Inflatable Restraint																									V	V																														
3	2012	ALL	Body	Theft Deterrent Module																																																								
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																								
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
3	2013	ALL	Chassis	Electronic Brake Control Module																																																								
3	2013	ALL	Chassis	Electronic Suspension Control																																																								
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																								
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																								
3	2013	ALL	Body	Amplifier (Bose)																																																								
3	2013	ALL	Body	Assist Step Controller																																																								
3	2013	ALL	Body	Body Control Module																																																								
3	2013	ALL	Body	Body Control Module (aux.)																																																								
3	2013	ALL	Body	Driver Door Switch																																																								
3	2013	ALL	Body	HVAC Control Module																																											V													
3	2013	ALL	Body	Inside Rear View Mirror Module																																																								
3	2013	ALL	Body	Instrument Panel Cluster																																																								
3	2013	ALL	Body	Left Side Object Detection Module																																																								
3	2013	ALL	Body	Lift Gate Module																																																								
3	2013	ALL	Body	Memory Seat Module																																																								
3	2013	ALL	Body	Park Assist Module																																																								
3	2013	ALL	Body	Passenger Door Switch																																																								
3	2013	ALL	Body	Passenger Presence System																																																								
3	2013	ALL	Body	Radio																																																								
3	2013	ALL	Body	Rear Heated Seat Module																																																								
3	2013	ALL	Body	Rear HVAC/RSA																																																								
3	2013	ALL	Body	Right Side Object Detection Module																																																								
3	2013	ALL	Body	Supplemental Inflatable Restraint																									V	V																														
3	2013	ALL	Body	Theft Deterrent Module																																																								
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																								
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																								
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump						V																																																		
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																								
3	2014	Escalade	Chassis	Suspension Control Module																																																								
3	2014	Escalade	Body	Body Control Module						V	V	V						V				V	V	V																																				
3	2014	Escalade	Body	Auxiliary Body Control Module																																																								
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
3	2014	Escalade	Body	Passenger Presence Module																										V																														
3	2014	Escalade	Body	Instrument Cluster																																																								
3	2014	Escalade	Body	Radio																																																								
3	2014	Escalade	Body	Amplifier																																																								
3	2014	Escalade	Body	Rear Audio Control Module																																																								
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																								
3	2014	Escalade	Body	Personal Audio Link Control Module																																																								
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
3	2014	Escalade	Body	HVAC Control Module																																												V	V			V								
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																	V																																						
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																								
3	2014	Escalade	Body	Liftgate Control Module																																																								
3	2014	Escalade	Body	Seat Memory Control Module																																					V	V																		
3	2014	Escalade	Body	Rear Seat Heating Control Module																																							V	V															
3	2014	Escalade	Body	Assist Step Control Module																																																							
3	2014	Escalade	Body	Right Side Object Detection Control Module																																									V	V													
3	2014	Escalade	Body	Left Side Object Detection Control Module																																									V	V													
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																							
3	2014	Escalade	Body	Parking Assist Control Module																																																							
3	2014	Escalade	Body	Theft Deterrent Module										V																																														
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																								
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																								
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump						V																																																	
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																								
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																								
3	2014	Escalade ESV	Body	Body Control Module						V	V	V						V				V	V	V																																				
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																								
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
3	2014	Escalade ESV	Body	Passenger Presence Module																										V																														
3	2014	Escalade ESV	Body	Instrument Cluster																																																								
3	2014	Escalade ESV	Body	Radio																																																								
3	2014	Escalade ESV	Body	Amplifier																																																								
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																								
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																								
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																								
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																					
3	2014	Escalade ESV	Body	HVAC Control Module																																											V	V			V								
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																	V																																							
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																								
3	2014	Escalade ESV	Body	Liftgate Control Module																																																								
3	2014	Escalade ESV	Body	Seat Memory Control Module																																					V	V																		
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																							V	V															
3	2014	Escalade ESV	Body	Assist Step Control Module																																																								
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																									V	V													
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																									V	V													
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																								
3	2014	Escalade ESV	Body	Parking Assist Control Module																																																								
3	2014	Escalade ESV	Body	Theft Deterrent Module										V																																														
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																	
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control						V																																																	
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																								
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																								
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																								
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																								
3	2015	Escalade	Chassis	Electronic Brake Control Module					V																																																			
3	2015	Escalade	Chassis	Parking Brake Control Module																																																								
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																								
3	2015	Escalade	Chassis	Power Steering Control Module																																																								
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
3	2015	Escalade	Chassis	Suspension Control Module																																																								
3	2015	Escalade	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																														V					
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																										
3	2015	Escalade	Body	Passenger Presence Module																															V																									
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																								
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																								
3	2015	Escalade	Body	Instrument Cluster																																V																								
3	2015	Escalade	Body	Radio/HVAC Control																																																								
3	2015	Escalade	Body	Active Safety Control Module																																																								
3	2015	Escalade	Body	Video Processing Control Module																																																								
3	2015	Escalade	Body	Radio																																																								
3	2015	Escalade	Body	Amplifier																																																								
3	2015	Escalade	Body	Media Disc Player																																																								
3	2015	Escalade	Body	Human Machine Interface Control Module																																																								
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																V	V	V	V																					
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																V	V	V																						
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
3	2015	Escalade	Body	HVAC Control Module																														V													V	V	V		V										
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																								
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																								
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																								
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																								
3	2015	Escalade	Body	Keyless Entry Control Module																																																								
3	2015	Escalade	Body	Assist Step Control Module																																																								
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																								
3	2015	Escalade	Body	Parking Assist Control Module																																V																								
3	2015	Escalade	Body	Frontview Camera Module																																																								
3	2015	Escalade	Body	Steering Column Lock Control Module																																																								
3	2015	Escalade	Body	Battery Energy Control Module																																																								
3	2015	Escalade	Body	Long Range Radar Sensor Module																																																								
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																								
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																								
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																								
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																								
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																		
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control						V																																																		
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																								
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module					V																																																					
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																																										
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
3	2015	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2015	Escalade ESV	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																								V							
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
3	2015	Escalade ESV	Body	Passenger Presence Module																																V																									
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																									
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																									
3	2015	Escalade ESV	Body	Instrument Cluster																																	V																								
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																									
3	2015	Escalade ESV	Body	Active Safety Control Module																																																									
3	2015	Escalade ESV	Body	Video Processing Control Module																																																									
3	2015	Escalade ESV	Body	Radio																																																									
3	2015	Escalade ESV	Body	Amplifier																																																									
3	2015	Escalade ESV	Body	Media Disc Player																																																									
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																									
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																	V	V	V	V																					
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
3	2015	Escalade ESV	Body	HVAC Control Module																														V														V	V	V		V							
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																									
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																									
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																									
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																									
3	2015	Escalade ESV	Body	Assist Step Control Module																																																									
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																									
3	2015	Escalade ESV	Body	Parking Assist Control Module																																V																									
3	2015	Escalade ESV	Body	Frontview Camera Module																																																									
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																									
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																									
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																									
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																									
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																									
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																									
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																					
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
3	2016	Escalade	Chassis	Electronic Brake Control Module					V																																																					
3	2016	Escalade	Chassis	Parking Brake Control Module																																																										
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																									
3	2016	Escalade	Chassis	Power Steering Control Module																																																									
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
3	2016	Escalade	Chassis	Suspension Control Module																																																										
3	2016	Escalade	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																								V							
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
3	2016	Escalade	Body	Passenger Presence Module																																V																								
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																							
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																							
3	2016	Escalade	Body	Instrument Cluster																																	V																							
3	2016	Escalade	Body	Radio/HVAC Control																																																							
3	2016	Escalade	Body	Active Safety Control Module																																																							
3	2016	Escalade	Body	Video Processing Control Module																																																							
3	2016	Escalade	Body	Radio																																																							
3	2016	Escalade	Body	Amplifier																																																							
3	2016	Escalade	Body	Media Disc Player																																																							
3	2016	Escalade	Body	Human Machine Interface Control Module																																																							
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																	V	V	V																					
3	2016	Escalade	Body	HVAC Control Module																														V													V	V	V		V								
3	2016	Escalade	Body	Liftgate Control Module																																																							
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																							
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																							
3	2016	Escalade	Body	Keyless Entry Control Module																																																							
3	2016	Escalade	Body	Assist Step Control Module																																																							
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																							
3	2016	Escalade	Body	Parking Assist Control Module																																	V																							
3	2016	Escalade	Body	Frontview Camera Module																																																							
3	2016	Escalade	Body	Steering Column Lock Control Module																																																							
3	2016	Escalade	Body	Long Range Radar Sensor Module																																																							
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																							
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																							
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																							
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																							
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																							
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																							
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																							
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																							
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module					V																																																		
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																							
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																							
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																																							
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
3	2016	Escalade ESV	Chassis	Suspension Control Module																																																							
3	2016	Escalade ESV	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																								V						
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
3	2016	Escalade ESV	Body	Passenger Presence Module																																V																							
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																						
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																						
3	2016	Escalade ESV	Body	Instrument Cluster																																	V																							
3	2016	Escalade ESV	Body	Radio Control																																																							
3	2016	Escalade ESV	Body	HVAC Control																																																							
3	2016	Escalade ESV	Body	Active Safety Control Module																																																							
3	2016	Escalade ESV	Body	Video Processing Control Module																																																							
3	2016	Escalade ESV	Body	Radio																																																						
3	2016	Escalade ESV	Body	Amplifier																																																						
3	2016	Escalade ESV	Body	Media Disc Player																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																									
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																	V	V	V																					
3	2016	Escalade ESV	Body	HVAC Control Module																														V												V	V	V		V										
3	2016	Escalade ESV	Body	Liftgate Control Module																																																								
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																								
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																								
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																								
3	2016	Escalade ESV	Body	Assist Step Control Module																																																								
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																								
3	2016	Escalade ESV	Body	Parking Assist Control Module																																V																									
3	2016	Escalade ESV	Body	Frontview Camera Module																																																								
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																								
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																								
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																								
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																								
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																								
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																								
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																								
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
4	2011	ALL	Chassis	Electronic Brake Control Module																																																								
4	2011	ALL	Chassis	Electronic Suspension Control																																																								
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																								
4	2011	ALL	Body	Amplifier (Bose)																																																								
4	2011	ALL	Body	Assist Step Controller																																																								
4	2011	ALL	Body	Body Control Module																																																								
4	2011	ALL	Body	Body Control Module (aux.)																																																								
4	2011	ALL	Body	Driver Door Switch																																																								
4	2011	ALL	Body	HVAC Control Module																																											V													
4	2011	ALL	Body	Inside Rear View Mirror Module																																																								
4	2011	ALL	Body	Instrument Panel Cluster																																																								
4	2011	ALL	Body	Left Side Object Detection Module																																																								
4	2011	ALL	Body	Lift Gate Module																																																								
4	2011	ALL	Body	Memory Seat Module																																																								
4	2011	ALL	Body	Park Assist Module																																																								
4	2011	ALL	Body	Passenger Door Switch																																																								
4	2011	ALL	Body	Passenger Presence System																																																								
4	2011	ALL	Body	Radio																																																								
4	2011	ALL	Body	Rear Heated Seat Module																																																								
4	2011	ALL	Body	Rear HVAC/RSA																																																								
4	2011	ALL	Body	Right Side Object Detection Module																																																								
4	2011	ALL	Body	Supplemental Inflatable Restraint																									V	V																														
4	2011	ALL	Body	Theft Deterrent Module																																																								
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																								
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
4	2012	ALL	Chassis	Electronic Brake Control Module																																																										
4	2012	ALL	Chassis	Electronic Suspension Control																																																									
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																									
4	2012	ALL	Body	Amplifier (Bose)																																																									
4	2012	ALL	Body	Assist Step Controller																																																									
4	2012	ALL	Body	Body Control Module																																																									
4	2012	ALL	Body	Body Control Module (aux.)																																																									
4	2012	ALL	Body	Driver Door Switch																																																									
4	2012	ALL	Body	HVAC Control Module																																												V														
4	2012	ALL	Body	Inside Rear View Mirror Module																																																									
4	2012	ALL	Body	Instrument Panel Cluster																																																									
4	2012	ALL	Body	Left Side Object Detection Module																																																									
4	2012	ALL	Body	Lift Gate Module																																																									
4	2012	ALL	Body	Memory Seat Module																																																									
4	2012	ALL	Body	Park Assist Module																																																									
4	2012	ALL	Body	Passenger Door Switch																																																									
4	2012	ALL	Body	Passenger Presence System																																																									
4	2012	ALL	Body	Radio																																																									
4	2012	ALL	Body	Rear Heated Seat Module																																																									
4	2012	ALL	Body	Rear HVAC/RSA																																																									
4	2012	ALL	Body	Right Side Object Detection Module																																																									
4	2012	ALL	Body	Supplemental Inflatable Restraint																									V	V																															
4	2012	ALL	Body	Theft Deterrent Module																																																									
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
4	2013	ALL	Chassis	Electronic Brake Control Module																																																									
4	2013	ALL	Chassis	Electronic Suspension Control																																																									
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																									
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																									
4	2013	ALL	Body	Amplifier (Bose)																																																									
4	2013	ALL	Body	Assist Step Controller																																																									
4	2013	ALL	Body	Body Control Module																																																									
4	2013	ALL	Body	Body Control Module (aux.)																																																									
4	2013	ALL	Body	Driver Door Switch																																																									
4	2013	ALL	Body	HVAC Control Module																																												V														
4	2013	ALL	Body	Inside Rear View Mirror Module																																																									
4	2013	ALL	Body	Instrument Panel Cluster																																																									
4	2013	ALL	Body	Left Side Object Detection Module																																																									
4	2013	ALL	Body	Lift Gate Module																																																									
4	2013	ALL	Body	Memory Seat Module																																																									
4	2013	ALL	Body	Park Assist Module																																																									
4	2013	ALL	Body	Passenger Door Switch																																																									
4	2013	ALL	Body	Passenger Presence System																																																									
4	2013	ALL	Body	Radio																																																									
4	2013	ALL	Body	Rear Heated Seat Module																																																									
4	2013	ALL	Body	Rear HVAC/RSA																																																									
4	2013	ALL	Body	Right Side Object Detection Module																																																									
4	2013	ALL	Body	Supplemental Inflatable Restraint																									V	V																															
4	2013	ALL	Body	Theft Deterrent Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump						V																																																				
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade	Chassis	Suspension Control Module																																																										
4	2014	Escalade	Body	Body Control Module						V	V	V						V				V	V	V																																						
4	2014	Escalade	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																												
4	2014	Escalade	Body	Passenger Presence Module																										V																																
4	2014	Escalade	Body	Instrument Cluster																																																										
4	2014	Escalade	Body	Radio																																																										
4	2014	Escalade	Body	Amplifier																																																										
4	2014	Escalade	Body	Rear Audio Control Module																																																										
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																							
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																								
4	2014	Escalade	Body	HVAC Control Module																																										V	V			V												
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																	V																																									
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Liftgate Control Module																																																										
4	2014	Escalade	Body	Seat Memory Control Module																																					V	V																				
4	2014	Escalade	Body	Rear Seat Heating Control Module																																							V	V																		
4	2014	Escalade	Body	Assist Step Control Module																																																										
4	2014	Escalade	Body	Right Side Object Detection Control Module																																									V	V																
4	2014	Escalade	Body	Left Side Object Detection Control Module																																									V	V																
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																																										
4	2014	Escalade	Body	Parking Assist Control Module																																																										
4	2014	Escalade	Body	Theft Deterrent Module										V																																																
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump						V																																																				
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2014	Escalade ESV	Body	Body Control Module						V	V	V						V				V	V	V																																						
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																												
4	2014	Escalade ESV	Body	Passenger Presence Module																										V																																
4	2014	Escalade ESV	Body	Instrument Cluster																																																										
4	2014	Escalade ESV	Body	Radio																																																										
4	2014	Escalade ESV	Body	Amplifier																																																										
4	2014	Escalade ESV	Body	Rear Audio Control Module																																																										
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																							
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																								
4	2014	Escalade ESV	Body	HVAC Control Module																																										V	V			V												
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																	V																																									
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
4	2014	Escalade ESV	Body	Liftgate Control Module																																																								
4	2014	Escalade ESV	Body	Seat Memory Control Module																																						V	V																		
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module										V																														V	V																
4	2014	Escalade ESV	Body	Assist Step Control Module																																																								
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																										V	V													
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																										V	V													
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																								
4	2014	Escalade ESV	Body	Parking Assist Control Module																																																								
4	2014	Escalade ESV	Body	Theft Deterrent Module										V																																														
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																		
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control						V																																																		
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																								
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																								
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																								
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																								
4	2015	Escalade	Chassis	Electronic Brake Control Module					V																																																			
4	2015	Escalade	Chassis	Parking Brake Control Module																																																								
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																								
4	2015	Escalade	Chassis	Power Steering Control Module																																																								
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
4	2015	Escalade	Chassis	Suspension Control Module																																																								
4	2015	Escalade	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																														V					
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																			V	V	V	V	V	V	V																															
4	2015	Escalade	Body	Passenger Presence Module																															V																									
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																								
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																								
4	2015	Escalade	Body	Instrument Cluster																																V																								
4	2015	Escalade	Body	Radio/HVAC Control																																																								
4	2015	Escalade	Body	Active Safety Control Module																																																								
4	2015	Escalade	Body	Video Processing Control Module																																																								
4	2015	Escalade	Body	Radio																																																								
4	2015	Escalade	Body	Amplifier																																																								
4	2015	Escalade	Body	Media Disc Player																																																								
4	2015	Escalade	Body	Human Machine Interface Control Module																																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																V	V	V	V																					
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																V	V	V																						
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
4	2015	Escalade	Body	HVAC Control Module																														V														V	V	V		V									
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																								
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																								
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																								
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																								
4	2015	Escalade	Body	Keyless Entry Control Module																																																								
4	2015	Escalade	Body	Assist Step Control Module																																																								
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
4	2015	Escalade	Body	Parking Assist Control Module																																	V																							
4	2015	Escalade	Body	Frontview Camera Module																																																								
4	2015	Escalade	Body	Steering Column Lock Control Module																																																								
4	2015	Escalade	Body	Battery Energy Control Module																																																								
4	2015	Escalade	Body	Long Range Radar Sensor Module																																																								
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																								
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																								
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																								
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																								
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																	
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control						V																																																	
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																								
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module					V																																																			
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																								
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																								
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																																								
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
4	2015	Escalade ESV	Chassis	Suspension Control Module																																																								
4	2015	Escalade ESV	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																								V							
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
4	2015	Escalade ESV	Body	Passenger Presence Module																																V																								
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																							
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																							
4	2015	Escalade ESV	Body	Instrument Cluster																																V																								
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																							
4	2015	Escalade ESV	Body	Active Safety Control Module																																																							
4	2015	Escalade ESV	Body	Video Processing Control Module																																																							
4	2015	Escalade ESV	Body	Radio																																																						
4	2015	Escalade ESV	Body	Amplifier																																																						
4	2015	Escalade ESV	Body	Media Disc Player																																																						
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																						
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																	V	V	V	V																		
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																		
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																		
4	2015	Escalade ESV	Body	HVAC Control Module																														V												V	V	V		V								
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																						
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																						
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																						
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																						
4	2015	Escalade ESV	Body	Assist Step Control Module																																																						
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																						
4	2015	Escalade ESV	Body	Parking Assist Control Module																																V																							
4	2015	Escalade ESV	Body	Frontview Camera Module																																																						
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																								
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																								
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																								
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																								
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																								
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
4	2016	Escalade	Chassis	Electronic Brake Control Module					V																																																			
4	2016	Escalade	Chassis	Parking Brake Control Module																																																								
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																								
4	2016	Escalade	Chassis	Power Steering Control Module																																																								
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
4	2016	Escalade	Chassis	Suspension Control Module																																																								
4	2016	Escalade	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																											V					
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																								
4	2016	Escalade	Body	Passenger Presence Module																																V																								
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																								
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																								
4	2016	Escalade	Body	Instrument Cluster																																	V																							
4	2016	Escalade	Body	Radio/HVAC Control																																																								
4	2016	Escalade	Body	Active Safety Control Module																																																								
4	2016	Escalade	Body	Video Processing Control Module																																																								
4	2016	Escalade	Body	Radio																																																								
4	2016	Escalade	Body	Amplifier																																																								
4	2016	Escalade	Body	Media Disc Player																																																								
4	2016	Escalade	Body	Human Machine Interface Control Module																																																								
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																	V	V	V																					
4	2016	Escalade	Body	HVAC Control Module																															V													V	V	V		V								
4	2016	Escalade	Body	Liftgate Control Module																																																								
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																								
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																								
4	2016	Escalade	Body	Keyless Entry Control Module																																																								
4	2016	Escalade	Body	Assist Step Control Module																																																								
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																								
4	2016	Escalade	Body	Parking Assist Control Module																																V																								
4	2016	Escalade	Body	Frontview Camera Module																																																								
4	2016	Escalade	Body	Steering Column Lock Control Module																																																								
4	2016	Escalade	Body	Long Range Radar Sensor Module																																																								
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																								
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																								
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																								
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																								
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module					V																																																			

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																								
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																								
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																																								
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
4	2016	Escalade ESV	Chassis	Suspension Control Module																																																								
4	2016	Escalade ESV	Body	Body Control Module						V	V	V		V	V		V		V		V	V	V	V	V	V	V	V																																
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
4	2016	Escalade ESV	Body	Passenger Presence Module																															V																									
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																								
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																								
4	2016	Escalade ESV	Body	Instrument Cluster																																V																								
4	2016	Escalade ESV	Body	Radio Control																																																								
4	2016	Escalade ESV	Body	HVAC Control																																																								
4	2016	Escalade ESV	Body	Active Safety Control Module																																																								
4	2016	Escalade ESV	Body	Video Processing Control Module																																																								
4	2016	Escalade ESV	Body	Radio																																																								
4	2016	Escalade ESV	Body	Amplifier																																																								
4	2016	Escalade ESV	Body	Media Disc Player																																																								
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																								
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																V	V	V																						
4	2016	Escalade ESV	Body	HVAC Control Module																														V													V	V	V		V									
4	2016	Escalade ESV	Body	Liftgate Control Module																																																								
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																								
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																								
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																								
4	2016	Escalade ESV	Body	Assist Step Control Module																																																								
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																								
4	2016	Escalade ESV	Body	Parking Assist Control Module																																V																								
4	2016	Escalade ESV	Body	Frontview Camera Module																																																								
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																								
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																								
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																								
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																								
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																								
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																								
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																								
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																								
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																								
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																								
ALL	2004	Hearse	Chassis	DRP/ABS/TCS																																																								
ALL	2004	Hearse	Chassis	Magna Steer																																																								
ALL	2004	Hearse	Chassis	Rear Integration Module																																																								
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																								
ALL	2004	Hearse	Body	Amplifier (Delco)																																																								
ALL	2004	Hearse	Body	Dash Integration Module																																																								
ALL	2004	Hearse	Body	Driver Door Switch																																																								
ALL	2004	Hearse	Body	Driver Door Module																																																								
ALL	2004	Hearse	Body	Passenger Door Module																																																								
ALL	2004	Hearse	Body	Instrument Panel Cluster																																																								
ALL	2004	Hearse	Body	Instrument Panel Module																																											V													
ALL	2004	Hearse	Body	Personalization																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
ALL	2004	Hearse	Body	Radio																																																								
ALL	2004	Hearse	Body	Rear Integration Module																																																								
ALL	2004	Hearse	Body	Remote Function Actuation																																																								
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																																																								
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																																								
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																								
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																								
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																								
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																								
ALL	2004	Limousine	Chassis	DRP/ABS/TCS																																																								
ALL	2004	Limousine	Chassis	Magna Steer																																																								
ALL	2004	Limousine	Chassis	Rear Integration Module																																																								
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																								
ALL	2004	Limousine	Body	Amplifier (Delco)																																																								
ALL	2004	Limousine	Body	Dash Integration Module																																																								
ALL	2004	Limousine	Body	Driver Door Switch																																																								
ALL	2004	Limousine	Body	Driver Door Module																																																								
ALL	2004	Limousine	Body	Passenger Door Module																																																								
ALL	2004	Limousine	Body	Left Mid Door Module																																																								
ALL	2004	Limousine	Body	Left Rear Door Module																																																								
ALL	2004	Limousine	Body	Right Mid Door Module																																																								
ALL	2004	Limousine	Body	Right Rear Door Module																																																								
ALL	2004	Limousine	Body	Instrument Panel Cluster																																																								
ALL	2004	Limousine	Body	Instrument Panel Module																																														V										
ALL	2004	Limousine	Body	Memory Seat Module																																																								
ALL	2004	Limousine	Body	Navigation Radio																																																								
ALL	2004	Limousine	Body	Personalization																																																								
ALL	2004	Limousine	Body	Radio																																																								
ALL	2004	Limousine	Body	Rear Climate Control Panel																																														V										
ALL	2004	Limousine	Body	Rear Integration Module																																																								
ALL	2004	Limousine	Body	Remote Function Actuation																																																								
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																																																								
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																																								
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																								
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																								
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																								
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																								
ALL	2005	Hearse	Chassis	DRP/ABS/TCS																																																								
ALL	2005	Hearse	Chassis	Magna Steer																																																								
ALL	2005	Hearse	Chassis	Rear Integration Module																																																								
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																								
ALL	2005	Hearse	Body	Amplifier (Delco)																																																								
ALL	2005	Hearse	Body	Dash Integration Module																																																								
ALL	2005	Hearse	Body	Driver Door Switch																																																								
ALL	2005	Hearse	Body	Driver Door Module																																																								
ALL	2005	Hearse	Body	Passenger Door Module																																																								
ALL	2005	Hearse	Body	Instrument Panel Cluster																																																								
ALL	2005	Hearse	Body	Instrument Panel Module																																														V										
ALL	2005	Hearse	Body	Personalization																																																								
ALL	2005	Hearse	Body	Radio																																																								
ALL	2005	Hearse	Body	Rear Integration Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
ALL	2005	Hearse	Body	Remote Function Actuation																																																								
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																																									
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																																									
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																									
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																									
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																									
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																									
ALL	2005	Limousine	Chassis	DRP/ABS/TCS																																																									
ALL	2005	Limousine	Chassis	Magna Steer																																																									
ALL	2005	Limousine	Chassis	Rear Integration Module																																																									
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																									
ALL	2005	Limousine	Body	Amplifier (Delco)																																																									
ALL	2005	Limousine	Body	Dash Integration Module																																																									
ALL	2005	Limousine	Body	Driver Door Switch																																																									
ALL	2005	Limousine	Body	Driver Door Module																																																									
ALL	2005	Limousine	Body	Passenger Door Module																																																									
ALL	2005	Limousine	Body	Left Mid Door Module																																																									
ALL	2005	Limousine	Body	Left Rear Door Module																																																									
ALL	2005	Limousine	Body	Right Mid Door Module																																																									
ALL	2005	Limousine	Body	Right Rear Door Module																																																									
ALL	2005	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2005	Limousine	Body	Instrument Panel Module																																												V													
ALL	2005	Limousine	Body	Memory Seat Module																																																									
ALL	2005	Limousine	Body	Navigation Radio																																																									
ALL	2005	Limousine	Body	Personalization																																																									
ALL	2005	Limousine	Body	Radio																																																									
ALL	2005	Limousine	Body	Rear Climate Control Panel																																												V													
ALL	2005	Limousine	Body	Rear Integration Module																																																									
ALL	2005	Limousine	Body	Remote Function Actuation																																																									
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint																																																									
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																																									
ALL	2006	Hearse	Powertrain	Engine Control Module																																																									
ALL	2006	Hearse	Powertrain	Transmission Control Module																																																									
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																																									
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																									
ALL	2006	Hearse	Body	Amplifier (Bose)																																																									
ALL	2006	Hearse	Body	Body Control Module																																																									
ALL	2006	Hearse	Body	Digital Radio Receiver																																																									
ALL	2006	Hearse	Body	Driver Door Switch																																																									
ALL	2006	Hearse	Body	Driver Position Module																																																									
ALL	2006	Hearse	Body	HVAC Control Module																																												V													
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																									
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																									
ALL	2006	Hearse	Body	Passenger Door Switch																																																									
ALL	2006	Hearse	Body	Passenger Presence System																																																									
ALL	2006	Hearse	Body	Radio																																																									
ALL	2006	Hearse	Body	Rear Heated Seat Module																																																									
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																									
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																																									
ALL	2006	Hearse	Body	Theft Deterrent Module																																																									
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																V																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
ALL	2006	Limousine	Powertrain	Engine Control Module																																																									
ALL	2006	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2006	Limousine	Body	Amplifier (Bose)																																																										
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2006	Limousine	Body	Body Control Module																																																										
ALL	2006	Limousine	Body	Digital Radio Receiver																																																										
ALL	2006	Limousine	Body	Driver Door Switch																																																										
ALL	2006	Limousine	Body	Driver Position Module																																																										
ALL	2006	Limousine	Body	HVAC Control Module																																												V															
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2006	Limousine	Body	Passenger Door Switch																																																										
ALL	2006	Limousine	Body	Passenger Presence System																																																										
ALL	2006	Limousine	Body	Radio																																																										
ALL	2006	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	Limousine	Body	Theft Deterrent Module																																																										
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																	V																									
ALL	2007	Hearse	Powertrain	Engine Control Module																																																										
ALL	2007	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Hearse	Body	Amplifier (Bose)																																																										
ALL	2007	Hearse	Body	Body Control Module																																																										
ALL	2007	Hearse	Body	Digital Radio Receiver																																																										
ALL	2007	Hearse	Body	Driver Door Switch																																																										
ALL	2007	Hearse	Body	Driver Position Module																																																										
ALL	2007	Hearse	Body	HVAC Control Module																																												V															
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2007	Hearse	Body	Passenger Door Switch																																																										
ALL	2007	Hearse	Body	Passenger Presence System																																																										
ALL	2007	Hearse	Body	Radio																																																										
ALL	2007	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	Hearse	Body	Theft Deterrent Module																																																										
ALL	2007	Limousine	Powertrain	Engine Control Module																																																										
ALL	2007	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Limousine	Body	Amplifier (Bose)																																																										
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2007	Limousine	Body	Body Control Module																																																										
ALL	2007	Limousine	Body	Digital Radio Receiver																																																										
ALL	2007	Limousine	Body	Driver Door Switch																																																										
ALL	2007	Limousine	Body	Driver Position Module																																																										
ALL	2007	Limousine	Body	HVAC Control Module																																												V															
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2007	Limousine	Body	Passenger Door Switch																																																										
ALL	2007	Limousine	Body	Passenger Presence System																																																										
ALL	2007	Limousine	Body	Radio																																																										
ALL	2007	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	Limousine	Body	Theft Deterrent Module																																																										
ALL	2008	Hearse	Powertrain	Engine Control Module																																																										
ALL	2008	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2008	Hearse	Body	Amplifier (Bose)																																																										
ALL	2008	Hearse	Body	Body Control Module																																																										
ALL	2008	Hearse	Body	Climate Control Seat Module																																																										
ALL	2008	Hearse	Body	Digital Radio Receiver																																																										
ALL	2008	Hearse	Body	Driver Door Switch																																																										
ALL	2008	Hearse	Body	Driver Position Module																																																										
ALL	2008	Hearse	Body	HVAC Control Module																																												V															
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2008	Hearse	Body	Passenger Door Switch																																																										
ALL	2008	Hearse	Body	Passenger Presence System																																																										
ALL	2008	Hearse	Body	Radio																																																										
ALL	2008	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	Hearse	Body	Theft Deterrent Module																																																										
ALL	2008	Limousine	Powertrain	Engine Control Module																																																										
ALL	2008	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2008	Limousine	Body	Amplifier (Bose)																																																										
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2008	Limousine	Body	Body Control Module																																																										
ALL	2008	Limousine	Body	Climate Control Seat Module																																																										
ALL	2008	Limousine	Body	Digital Radio Receiver																																																										
ALL	2008	Limousine	Body	Driver Door Switch																																																										
ALL	2008	Limousine	Body	Driver Position Module																																																										
ALL	2008	Limousine	Body	HVAC Control Module																																												V															
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2008	Limousine	Body	Passenger Door Switch																																																										
ALL	2008	Limousine	Body	Passenger Presence System																																																										
ALL	2008	Limousine	Body	Radio																																																										
ALL	2008	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	Limousine	Body	Theft Deterrent Module																																																										
ALL	2009	Hearse	Powertrain	Engine Control Module																																																										
ALL	2009	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2009	Hearse	Body	Amplifier (Bose)																																																										
ALL	2009	Hearse	Body	Body Control Module																																																										
ALL	2009	Hearse	Body	Climate Control Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
ALL	2009	Hearse	Body	Digital Radio Receiver																																																									
ALL	2009	Hearse	Body	Driver Door Switch																																																										
ALL	2009	Hearse	Body	Driver Position Module																																																										
ALL	2009	Hearse	Body	HVAC Control Module																																												V														
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2009	Hearse	Body	Passenger Door Switch																																																										
ALL	2009	Hearse	Body	Passenger Presence System																																																										
ALL	2009	Hearse	Body	Radio																																																										
ALL	2009	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	Hearse	Body	Theft Deterrent Module																																																										
ALL	2009	Limousine	Powertrain	Engine Control Module																																																										
ALL	2009	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2009	Limousine	Body	Amplifier (Bose)																																																										
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2009	Limousine	Body	Body Control Module																																																										
ALL	2009	Limousine	Body	Climate Control Seat Module																																																										
ALL	2009	Limousine	Body	Digital Radio Receiver																																																										
ALL	2009	Limousine	Body	Driver Door Switch																																																										
ALL	2009	Limousine	Body	Driver Position Module																																																										
ALL	2009	Limousine	Body	HVAC Control Module																																												V														
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2009	Limousine	Body	Passenger Door Switch																																																										
ALL	2009	Limousine	Body	Passenger Presence System																																																										
ALL	2009	Limousine	Body	Radio																																																										
ALL	2009	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	Limousine	Body	Theft Deterrent Module																																																										
ALL	2010	Hearse	Powertrain	Engine Control Module																																																										
ALL	2010	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2010	Hearse	Body	Amplifier (Bose)																																																										
ALL	2010	Hearse	Body	Body Control Module																																																										
ALL	2010	Hearse	Body	Climate Control Seat Module																																																										
ALL	2010	Hearse	Body	Digital Radio Receiver																																																										
ALL	2010	Hearse	Body	Driver Door Switch																																																										
ALL	2010	Hearse	Body	Driver Position Module																																																										
ALL	2010	Hearse	Body	HVAC Control Module																																												V														
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2010	Hearse	Body	Passenger Door Switch																																																										
ALL	2010	Hearse	Body	Passenger Presence System																																																										
ALL	2010	Hearse	Body	Radio																																																										
ALL	2010	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	Hearse	Body	Theft Deterrent Module																																																										
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																V		V																						
ALL	2010	Limousine	Powertrain	Engine Control Module																																																										
ALL	2010	Limousine	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																									
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2010	Limousine	Body	Amplifier (Bose)																																																										
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2010	Limousine	Body	Body Control Module																																																										
ALL	2010	Limousine	Body	Climate Control Seat Module																																																										
ALL	2010	Limousine	Body	Digital Radio Receiver																																																										
ALL	2010	Limousine	Body	Driver Door Switch																																																										
ALL	2010	Limousine	Body	Driver Position Module																																																										
ALL	2010	Limousine	Body	HVAC Control Module																																												V															
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2010	Limousine	Body	Passenger Door Switch																																																										
ALL	2010	Limousine	Body	Passenger Presence System																																																										
ALL	2010	Limousine	Body	Radio																																																										
ALL	2010	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	Limousine	Body	Theft Deterrent Module																																																										
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																V		V																								
ALL	2011	Hearse	Powertrain	Engine Control Module																																																										
ALL	2011	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2011	Hearse	Body	Amplifier (Bose)																																																										
ALL	2011	Hearse	Body	Body Control Module																																																										
ALL	2011	Hearse	Body	Climate Control Seat Module																																																										
ALL	2011	Hearse	Body	Digital Radio Receiver																																																										
ALL	2011	Hearse	Body	Driver Door Switch																																																										
ALL	2011	Hearse	Body	Driver Position Module																																																										
ALL	2011	Hearse	Body	HVAC Control Module																																												V															
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2011	Hearse	Body	Passenger Door Switch																																																										
ALL	2011	Hearse	Body	Passenger Presence System																																																										
ALL	2011	Hearse	Body	Radio																																																										
ALL	2011	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2011	Hearse	Body	Theft Deterrent Module																																																										
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																V		V																								
ALL	2011	Limousine	Powertrain	Engine Control Module																																																										
ALL	2011	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2011	Limousine	Body	Amplifier (Bose)																																																										
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2011	Limousine	Body	Body Control Module																																																										
ALL	2011	Limousine	Body	Climate Control Seat Module																																																										
ALL	2011	Limousine	Body	Digital Radio Receiver																																																										
ALL	2011	Limousine	Body	Driver Door Switch																																																										
ALL	2011	Limousine	Body	Driver Position Module																																																										
ALL	2011	Limousine	Body	HVAC Control Module																																												V															
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2011	Limousine	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
ALL	2011	Limousine	Body	Passenger Presence System																																																									
ALL	2011	Limousine	Body	Radio																																																									
ALL	2011	Limousine	Body	Rear Heated Seat Module																																																									
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																																									
ALL	2011	Limousine	Body	Theft Deterrent Module																																																									
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																	V		V																						

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2007	ALL	Body	Assist Step Controller																																																												
C	2007	ALL	Body	Body Control Module																																																												
C	2007	ALL	Body	Body Control Module (aux.)																																																												
C	2007	ALL	Body	Digital Radio Receiver																																																												
C	2007	ALL	Body	Driver Door Switch																																																												
C	2007	ALL	Body	HVAC Control Module																																																												
C	2007	ALL	Body	Inside Rear View Mirror Module																																																												
C	2007	ALL	Body	Instrument Panel Cluster																																																												
C	2007	ALL	Body	Lift Gate Module																																																												
C	2007	ALL	Body	Memory Seat Module																																																												
C	2007	ALL	Body	Park Assist Module																																																												
C	2007	ALL	Body	Passenger Door Switch																																																												
C	2007	ALL	Body	Passenger Presence System																																																												
C	2007	ALL	Body	Radio																																																												
C	2007	ALL	Body	Rear Heated Seat Module																																																												
C	2007	ALL	Body	Rear HVAC/RSA																																																												
C	2007	ALL	Body	Rollover Sensor																																																												
C	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2007	ALL	Body	Theft Deterrent Module																																																												
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	ALL	Chassis	Electronic Brake Control Module																																																												
C	2008	ALL	Chassis	Electronic Suspension Control																																																												
C	2008	ALL	Chassis	Trailer Brake Control Module																																																												
C	2008	ALL	Body	Amplifier (Bose)																																																												
C	2008	ALL	Body	Assist Step Controller																																																												
C	2008	ALL	Body	Body Control Module																																																												
C	2008	ALL	Body	Body Control Module (aux.)																																																												
C	2008	ALL	Body	Digital Radio Receiver																																																												
C	2008	ALL	Body	Driver Door Switch																																																												
C	2008	ALL	Body	HVAC Control Module																																																												
C	2008	ALL	Body	Inside Rear View Mirror Module																																																												
C	2008	ALL	Body	Instrument Panel Cluster																																																												
C	2008	ALL	Body	Lift Gate Module																																																												
C	2008	ALL	Body	Memory Seat Module																																																												
C	2008	ALL	Body	Park Assist Module																																																												
C	2008	ALL	Body	Passenger Door Switch																																																												
C	2008	ALL	Body	Passenger Presence System																																																												
C	2008	ALL	Body	Radio																																																												
C	2008	ALL	Body	Rear Heated Seat Module																																																												
C	2008	ALL	Body	Rear HVAC/RSA																																																												
C	2008	ALL	Body	Rollover Sensor																																																												
C	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2008	ALL	Body	Theft Deterrent Module																																																												
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	ALL	Chassis	Electronic Brake Control Module																																																												
C	2009	ALL	Chassis	Electronic Suspension Control																																																												
C	2009	ALL	Chassis	Trailer Brake Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2005	ALL	Body	Instrument Panel Cluster																																																										
E	2005	ALL	Body	Memory Seat Module																																																										
E	2005	ALL	Body	Personalization																																																										
E	2005	ALL	Body	Base Radio																																																										
E	2005	ALL	Body	Navigation Radio																																																										
E	2005	ALL	Body	Rear Integration Module																																																										
E	2005	ALL	Body	Rear Seat Module																																																										
E	2005	ALL	Body	Remote Function Actuation																																																										
E	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2005	ALL	Body	TV Antenna Module																																																										
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
E	2005	ALL	Body	Vehicle Theft Deterrent																																																										
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																										
E	2006	ALL	Chassis	Electronic Suspension Control																																																										
E	2006	ALL	Chassis	Tire Pressure Monitor																																																										
E	2006	ALL	Chassis	VES																																																										
E	2006	ALL	Body	Amplifier (Bose)																																																										
E	2006	ALL	Body	Amplifier (Delco)																																																										
E	2006	ALL	Body	Climate Control Panel																																																										
E	2006	ALL	Body	Dash Integration Module																																																										
E	2006	ALL	Body	Disc Player and Video Display																																																										
E	2006	ALL	Body	Driver Door Switch																																																										
E	2006	ALL	Body	Driver Door Module																																																										
E	2006	ALL	Body	Passenger Door Module																																																										
E	2006	ALL	Body	Left Rear Door Module																																																										
E	2006	ALL	Body	Right Rear Door Module																																																										
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2006	ALL	Body	Instrument Panel Cluster																																																										
E	2006	ALL	Body	Lift Gate Module																																																										
E	2006	ALL	Body	Memory Seat Module																																																										
E	2006	ALL	Body	Personalization																																																										
E	2006	ALL	Body	Base Radio																																																										
E	2006	ALL	Body	Navigation Radio																																																										
E	2006	ALL	Body	Rear Integration Module																																																										
E	2006	ALL	Body	Rear Seat Module																																																										
E	2006	ALL	Body	Remote Function Actuation																																																										
E	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
E	2006	ALL	Body	Vehicle Theft Deterrent																																																										
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2007	ALL	Chassis	Electronic Brake Control Module																																																										

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																												
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																												
N	2010	SRX	Body	Liftgate Control Module																																																												
N	2010	SRX	Body	Seat Memory Control Module																																																												
N	2010	SRX	Body	Front Seat Heating Control Module																																																												
N	2010	SRX	Body	Rear Seat Heating Control Module																																																												
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																												
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																												
N	2010	SRX	Body	Parking Assist Control Module																																							V	V	V																		
N	2010	SRX	Body	Steering Column Lock Control Module																																																												
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																												
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																												
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																												
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																												
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2011	SRX	Chassis	Electronic Brake Control Module											V	V	V	V	V																																													
N	2011	SRX	Chassis	Parking Brake Control Module																																																												
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2011	SRX	Chassis	Suspension Control Module																																																												
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2011	SRX	Body	Passenger Presence Module																																																												
N	2011	SRX	Body	Instrument Cluster																																																												
N	2011	SRX	Body	Headlamp Control Module																															V																													
N	2011	SRX	Body	Trailer Interface Control Module																																																												
N	2011	SRX	Body	Radio																																																											
N	2011	SRX	Body	Rear Audio Control Module																																																											
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																											
N	2011	SRX	Body	Multimedia Player Interface Module																																																											
N	2011	SRX	Body	Mobile Telephone Control Module																																																											
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																											
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																											
N	2011	SRX	Body	Liftgate Control Module																																																											
N	2011	SRX	Body	Seat Memory Control Module																																																											
N	2011	SRX	Body	Front Seat Heating Control Module																																																											
N	2011	SRX	Body	Rear Seat Heating Control Module																																																											
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2011	SRX	Body	Parking Assist Control Module																																							V	V	V																	
N	2011	SRX	Body	Steering Column Lock Control Module																																																											
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																											
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module							V																																																				

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
3	2012	ALL	Body	Radio																																																												
3	2012	ALL	Body	Rear Heated Seat Module																																																												
3	2012	ALL	Body	Rear HVAC/RSA																																																												
3	2012	ALL	Body	Right Side Object Detection Module																																																												
3	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
3	2012	ALL	Body	Theft Deterrent Module																																																												
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
3	2013	ALL	Chassis	Electronic Brake Control Module																																																												
3	2013	ALL	Chassis	Electronic Suspension Control																																																												
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																												
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																												
3	2013	ALL	Body	Amplifier (Bose)																																																												
3	2013	ALL	Body	Assist Step Controller																																																												
3	2013	ALL	Body	Body Control Module																																																												
3	2013	ALL	Body	Body Control Module (aux.)																																																												
3	2013	ALL	Body	Driver Door Switch																																																												
3	2013	ALL	Body	HVAC Control Module																																																												
3	2013	ALL	Body	Inside Rear View Mirror Module																																																												
3	2013	ALL	Body	Instrument Panel Cluster																																																												
3	2013	ALL	Body	Left Side Object Detection Module																																																												
3	2013	ALL	Body	Lift Gate Module																																																												
3	2013	ALL	Body	Memory Seat Module																																																												
3	2013	ALL	Body	Park Assist Module																																																												
3	2013	ALL	Body	Passenger Door Switch																																																												
3	2013	ALL	Body	Passenger Presence System																																																												
3	2013	ALL	Body	Radio																																																												
3	2013	ALL	Body	Rear Heated Seat Module																																																												
3	2013	ALL	Body	Rear HVAC/RSA																																																												
3	2013	ALL	Body	Right Side Object Detection Module																																																												
3	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
3	2013	ALL	Body	Theft Deterrent Module																																																												
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																												
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
3	2014	Escalade	Chassis	Electronic Brake Control Module											V	V	V	V	V																																													
3	2014	Escalade	Chassis	Suspension Control Module																																													V															
3	2014	Escalade	Body	Body Control Module		V															V																				V																							
3	2014	Escalade	Body	Auxiliary Body Control Module																																																												
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
3	2014	Escalade	Body	Passenger Presence Module																																																												
3	2014	Escalade	Body	Instrument Cluster																																																												
3	2014	Escalade	Body	Radio																																																												
3	2014	Escalade	Body	Amplifier																																																												
3	2014	Escalade	Body	Rear Audio Control Module																																																												
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																												
3	2014	Escalade	Body	Personal Audio Link Control Module																																																												
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																												
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
3	2014	Escalade	Body	HVAC Control Module																																																														
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																													
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																													
3	2014	Escalade	Body	Liftgate Control Module																																																													
3	2014	Escalade	Body	Seat Memory Control Module																																																													
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																													
3	2014	Escalade	Body	Assist Step Control Module																																																													
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																													
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																													
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																													
3	2014	Escalade	Body	Parking Assist Control Module																																																													
3	2014	Escalade	Body	Theft Deterrent Module																																																													
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																													
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																													
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																													
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																													
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module											V	V	V	V	V																																														
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																														
3	2014	Escalade ESV	Body	Body Control Module		V															V																																												
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																													
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
3	2014	Escalade ESV	Body	Passenger Presence Module																																																													
3	2014	Escalade ESV	Body	Instrument Cluster																																																													
3	2014	Escalade ESV	Body	Radio																																																													
3	2014	Escalade ESV	Body	Amplifier																																																													
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																													
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																													
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																													
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																													
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																													
3	2014	Escalade ESV	Body	HVAC Control Module																																																													
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																													
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																													
3	2014	Escalade ESV	Body	Liftgate Control Module																																																													
3	2014	Escalade ESV	Body	Seat Memory Control Module																																																													
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																													
3	2014	Escalade ESV	Body	Assist Step Control Module																																																													
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																													
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																													
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																													
3	2014	Escalade ESV	Body	Parking Assist Control Module																																																													
3	2014	Escalade ESV	Body	Theft Deterrent Module																																																													
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																													
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																													
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																													
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																													
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																													
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																													
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																		
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																											
3	2016	Escalade ESV	Body	HVAC Control Module																																																											
3	2016	Escalade ESV	Body	Liftgate Control Module																																																											
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																											
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																											
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																											
3	2016	Escalade ESV	Body	Assist Step Control Module																																																											
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																											
3	2016	Escalade ESV	Body	Frontview Camera Module																											V	V																															
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																											
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																											
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																											
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																											
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																											
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																											
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
4	2011	ALL	Chassis	Electronic Brake Control Module																																																											
4	2011	ALL	Chassis	Electronic Suspension Control																																																											
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2011	ALL	Body	Amplifier (Bose)																																																											
4	2011	ALL	Body	Assist Step Controller																																																											
4	2011	ALL	Body	Body Control Module																																																											
4	2011	ALL	Body	Body Control Module (aux.)																																																											
4	2011	ALL	Body	Driver Door Switch																																																											
4	2011	ALL	Body	HVAC Control Module																																																											
4	2011	ALL	Body	Inside Rear View Mirror Module																																																											
4	2011	ALL	Body	Instrument Panel Cluster																																																											
4	2011	ALL	Body	Left Side Object Detection Module																																																											
4	2011	ALL	Body	Lift Gate Module																																																											
4	2011	ALL	Body	Memory Seat Module																																																											
4	2011	ALL	Body	Park Assist Module																																																											
4	2011	ALL	Body	Passenger Door Switch																																																											
4	2011	ALL	Body	Passenger Presence System																																																											
4	2011	ALL	Body	Radio																																																											
4	2011	ALL	Body	Rear Heated Seat Module																																																											
4	2011	ALL	Body	Rear HVAC/RSA																																																											
4	2011	ALL	Body	Right Side Object Detection Module																																																											
4	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
4	2011	ALL	Body	Theft Deterrent Module																																																											
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
4	2014	Escalade ESV	Body	Liftgate Control Module																																																										
4	2014	Escalade ESV	Body	Seat Memory Control Module																																																										
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																										
4	2014	Escalade ESV	Body	Assist Step Control Module																																																										
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																										
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																										
4	2014	Escalade ESV	Body	Parking Assist Control Module																																																										
4	2014	Escalade ESV	Body	Theft Deterrent Module																																																										
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																										
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																										
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																										
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																										
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																										
4	2015	Escalade	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																												
4	2015	Escalade	Chassis	Parking Brake Control Module																																																										
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2015	Escalade	Chassis	Power Steering Control Module																			V													V																										
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2015	Escalade	Chassis	Suspension Control Module																																																										
4	2015	Escalade	Body	Body Control Module									V																																																
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2015	Escalade	Body	Passenger Presence Module																																																										
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2015	Escalade	Body	Instrument Cluster																																																										
4	2015	Escalade	Body	Radio/HVAC Control																																																										
4	2015	Escalade	Body	Active Safety Control Module																																																		V	V	V	V	V	V	V	V	V	V
4	2015	Escalade	Body	Video Processing Control Module																																																										
4	2015	Escalade	Body	Radio																		V	V																																						
4	2015	Escalade	Body	Amplifier																				V	V																																			
4	2015	Escalade	Body	Media Disc Player																																																										
4	2015	Escalade	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																										
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																										
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2015	Escalade	Body	HVAC Control Module																																																										
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																										
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																										
4	2015	Escalade	Body	Keyless Entry Control Module																																																										
4	2015	Escalade	Body	Assist Step Control Module																																																										
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																										

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																												
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																				
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																					V	V	V																				
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																					V	V	V																				
C	2004	ALL	Body	Driver Seat Module																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
C	2004	ALL	Body	Instrument Panel Cluster																																																											
C	2004	ALL	Body	OnStar																																																										
C	2004	ALL	Body	Passenger Door Module																																					V	V	V																				
C	2004	ALL	Body	Passenger Presence System																																																											
C	2004	ALL	Body	Base Radio																																																											
C	2004	ALL	Body	Uplevel Radio																																																											
C	2004	ALL	Body	Navigation Radio																																																											
C	2004	ALL	Body	Rear Aux. Climate Module																																					V																						
C	2004	ALL	Body	Rear HVAC																																																											
C	2004	ALL	Body	Rear Seat Audio																																					V																						
C	2004	ALL	Body	Rear Seat Entertainment																																																											
C	2004	ALL	Body	Supplemental Inflatable Restraint																																					V	V																					
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																				
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	ESC																																																									
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2005	ALL	Chassis	VSES																																																									
C	2005	ALL	Body	Amplifier (Bose)																																																										
C	2005	ALL	Body	Body Control Module																																					V	V	V																				
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																					V	V	V																				
C	2005	ALL	Body	Driver Seat Module																																																										
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2005	ALL	Body	Instrument Panel Cluster																																																										
C	2005	ALL	Body	Passenger Door Module																																					V	V	V																			
C	2005	ALL	Body	Passenger Presence System																																																										
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio																																																										
C	2005	ALL	Body	Rear Aux. Climate Module																																					V																						
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																					V																						
C	2005	ALL	Body	Remote Function Actuation																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint																																					V																						V
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																												
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																				
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																										
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																					V	V	V																			
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																					V	V	V																			
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																					V	V	V																			
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																					V																						
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																					V																						
C	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																						V
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																												
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																V	V																									
C	2007	ALL	Chassis	Electronic Brake Control Module																																																										
C	2007	ALL	Chassis	Electronic Suspension Control																																																										
C	2007	ALL	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2007	ALL	Body	Assist Step Controller																																																								
C	2007	ALL	Body	Body Control Module			V																																			V	V																	
C	2007	ALL	Body	Body Control Module (aux.)																																																								
C	2007	ALL	Body	Digital Radio Receiver																																																								
C	2007	ALL	Body	Driver Door Switch																																					V	V	V																		
C	2007	ALL	Body	HVAC Control Module																																						V		V																	
C	2007	ALL	Body	Inside Rear View Mirror Module																																																								
C	2007	ALL	Body	Instrument Panel Cluster																																																								
C	2007	ALL	Body	Lift Gate Module																																					V																			
C	2007	ALL	Body	Memory Seat Module																																																								
C	2007	ALL	Body	Park Assist Module																																																								
C	2007	ALL	Body	Passenger Door Switch																																					V	V	V																		
C	2007	ALL	Body	Passenger Presence System																																					V																			
C	2007	ALL	Body	Radio																																																								
C	2007	ALL	Body	Rear Heated Seat Module																																																								
C	2007	ALL	Body	Rear HVAC/RSA																																																								
C	2007	ALL	Body	Rollover Sensor																																																								
C	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																			
C	2007	ALL	Body	Theft Deterrent Module																																																								
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																											
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																							
C	2008	ALL	Chassis	Electronic Brake Control Module																																			V																					
C	2008	ALL	Chassis	Electronic Suspension Control																																																								
C	2008	ALL	Chassis	Trailer Brake Control Module																																																								
C	2008	ALL	Body	Amplifier (Bose)																																																								
C	2008	ALL	Body	Assist Step Controller																																																								
C	2008	ALL	Body	Body Control Module			V																																			V	V																	
C	2008	ALL	Body	Body Control Module (aux.)																																																								
C	2008	ALL	Body	Digital Radio Receiver																																																								
C	2008	ALL	Body	Driver Door Switch																																					V	V	V																		
C	2008	ALL	Body	HVAC Control Module																																							V		V																
C	2008	ALL	Body	Inside Rear View Mirror Module																																																								
C	2008	ALL	Body	Instrument Panel Cluster																																																								
C	2008	ALL	Body	Lift Gate Module																																					V																			
C	2008	ALL	Body	Memory Seat Module																																																								
C	2008	ALL	Body	Park Assist Module																																																								
C	2008	ALL	Body	Passenger Door Switch																																					V	V	V																		
C	2008	ALL	Body	Passenger Presence System																																					V																			
C	2008	ALL	Body	Radio																																																								
C	2008	ALL	Body	Rear Heated Seat Module																																																								
C	2008	ALL	Body	Rear HVAC/RSA																																																								
C	2008	ALL	Body	Rollover Sensor																																																								
C	2008	ALL	Body	Supplemental Inflatable Restraint																																					V																			
C	2008	ALL	Body	Theft Deterrent Module																																																								
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																											
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																							
C	2009	ALL	Chassis	Electronic Brake Control Module																																			V																			
C	2009	ALL	Chassis	Electronic Suspension Control																																																								
C	2009	ALL	Chassis	Trailer Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2009	ALL	Body	Amplifier (Bose)																																																								
C	2009	ALL	Body	Assist Step Controller																																																								
C	2009	ALL	Body	Body Control Module			V																																			V	V																	
C	2009	ALL	Body	Body Control Module (aux.)																																																								
C	2009	ALL	Body	Digital Radio Receiver																																																								
C	2009	ALL	Body	Driver Door Switch																																				V	V	V																		
C	2009	ALL	Body	HVAC Control Module																																						V		V																	
C	2009	ALL	Body	Inside Rear View Mirror Module																																																								
C	2009	ALL	Body	Instrument Panel Cluster																																																								
C	2009	ALL	Body	Left Side Object Detection Module																																																								
C	2009	ALL	Body	Lift Gate Module																																				V																				
C	2009	ALL	Body	Memory Seat Module																																																								
C	2009	ALL	Body	Park Assist Module																																																								
C	2009	ALL	Body	Passenger Door Switch																																				V	V	V																		
C	2009	ALL	Body	Passenger Presence System																																				V																				
C	2009	ALL	Body	Radio																																																								
C	2009	ALL	Body	Rear Heated Seat Module																																																								
C	2009	ALL	Body	Rear HVAC/RSA																																																								
C	2009	ALL	Body	Right Side Object Detection Module																																																								
C	2009	ALL	Body	Rollover Sensor																																																								
C	2009	ALL	Body	Supplemental Inflatable Restraint																																				V																				
C	2009	ALL	Body	Theft Deterrent Module																																																								
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																											
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																V	V																							
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																											
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																V	V																							
C	2010	ALL	Chassis	Electronic Brake Control Module																																			V																				
C	2010	ALL	Chassis	Electronic Suspension Control																																																								
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	ALL	Body	Amplifier (Bose)																																																								
C	2010	ALL	Body	Assist Step Controller																																																								
C	2010	ALL	Body	Body Control Module			V																																			V	V																	
C	2010	ALL	Body	Body Control Module (aux.)																																																								
C	2010	ALL	Body	Digital Radio Receiver																																																								
C	2010	ALL	Body	Driver Door Switch																																				V	V	V																		
C	2010	ALL	Body	HVAC Control Module																																						V		V																	
C	2010	ALL	Body	Inside Rear View Mirror Module																																																								
C	2010	ALL	Body	Instrument Panel Cluster																																																								
C	2010	ALL	Body	Left Side Object Detection Module																																																								
C	2010	ALL	Body	Lift Gate Module																																				V																				
C	2010	ALL	Body	Memory Seat Module																																																								
C	2010	ALL	Body	Park Assist Module																																																								
C	2010	ALL	Body	Passenger Door Switch																																				V	V	V																		
C	2010	ALL	Body	Passenger Presence System																																				V																				
C	2010	ALL	Body	Radio																																																								
C	2010	ALL	Body	Rear Heated Seat Module																																																								
C	2010	ALL	Body	Rear HVAC/RSA																																																								
C	2010	ALL	Body	Right Side Object Detection Module																																																								
C	2010	ALL	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2010	ALL	Body	Theft Deterrent Module																																																										
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module													V	V													V	V	V	V	V																											
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																								
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module													V														V	V	V	V	V																											
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																								
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																			V	V	V																					
E	2004	ALL	Chassis	Electronic Suspension Control																																							V	V																		
E	2004	ALL	Chassis	Tire Pressure Monitor																																																										
E	2004	ALL	Chassis	VES																																																										
E	2004	ALL	Body	Amplifier (Bose)																																						V	V	V																		
E	2004	ALL	Body	Amplifier (Delco)																																						V	V	V																		
E	2004	ALL	Body	Climate Control Panel																																									V	V	V	V	V													
E	2004	ALL	Body	Dash Integration Module																																						V	V	V						V	V	V										
E	2004	ALL	Body	Disc Player and Video Display																																																										
E	2004	ALL	Body	Driver Door Switch																																						V	V																			
E	2004	ALL	Body	Driver Door Module																																						V	V	V						V		V	V									
E	2004	ALL	Body	Passenger Door Module																																						V	V	V						V		V	V									
E	2004	ALL	Body	Left Rear Door Module																																						V	V	V									V									
E	2004	ALL	Body	Right Rear Door Module																																						V	V	V									V									
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2004	ALL	Body	Instrument Panel Cluster																																						V	V																			
E	2004	ALL	Body	Memory Seat Module																																						V	V	V											V	V						
E	2004	ALL	Body	OnStar																																																										
E	2004	ALL	Body	Personalization																																																				V	V					
E	2004	ALL	Body	Base Radio																																															V										V	
E	2004	ALL	Body	Navigation Radio																																																									V	
E	2004	ALL	Body	Rear Integration Module																																						V	V	V															V			
E	2004	ALL	Body	Rear Seat Module																																						V	V	V																		
E	2004	ALL	Body	Remote Function Actuation																																																										
E	2004	ALL	Body	Supplemental Inflatable Restraint																																						V																				V
E	2004	ALL	Body	TV Antenna Module																																						V	V	V																		
E	2004	ALL	Body	Vehicle Theft Deterrent																																						V																				
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module													V	V													V	V	V	V	V																											
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																								
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module													V														V	V	V	V	V																											
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																								
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																			V	V	V																					
E	2005	ALL	Chassis	Electronic Suspension Control																																							V	V																		
E	2005	ALL	Chassis	Tire Pressure Monitor																																																										
E	2005	ALL	Chassis	VES																																																										
E	2005	ALL	Body	Amplifier (Bose)																																						V	V	V																		
E	2005	ALL	Body	Amplifier (Delco)																																						V	V	V																		
E	2005	ALL	Body	Climate Control Panel																																									V	V	V	V	V													
E	2005	ALL	Body	Dash Integration Module																																						V	V	V						V	V	V										
E	2005	ALL	Body	Disc Player and Video Display																																																										
E	2005	ALL	Body	Driver Door Switch																																						V	V																			
E	2005	ALL	Body	Driver Door Module																																						V	V	V						V		V	V									
E	2005	ALL	Body	Passenger Door Module																																						V	V	V						V		V	V									
E	2005	ALL	Body	Left Rear Door Module																																						V	V	V									V									
E	2005	ALL	Body	Right Rear Door Module																																						V	V	V									V									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2005	ALL	Body	Instrument Panel Cluster																																						V	V																			
E	2005	ALL	Body	Memory Seat Module																																						V	V	V											V	V						
E	2005	ALL	Body	Personalization																																																					V	V				
E	2005	ALL	Body	Base Radio																																																V										V
E	2005	ALL	Body	Navigation Radio																																																										V
E	2005	ALL	Body	Rear Integration Module																																						V	V	V																	V	
E	2005	ALL	Body	Rear Seat Module																																						V	V	V																		
E	2005	ALL	Body	Remote Function Actuation																																																										
E	2005	ALL	Body	Supplemental Inflatable Restraint																																						V																				V
E	2005	ALL	Body	TV Antenna Module																																						V	V	V																		
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
E	2005	ALL	Body	Vehicle Theft Deterrent																																						V																				
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V	V	V	V	V																											
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																								
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module													V														V	V	V	V	V																											
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																								
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																			V	V	V																					
E	2006	ALL	Chassis	Electronic Suspension Control																																							V	V																		
E	2006	ALL	Chassis	Tire Pressure Monitor																																																										
E	2006	ALL	Chassis	VES																																																										
E	2006	ALL	Body	Amplifier (Bose)																																						V	V	V																		
E	2006	ALL	Body	Amplifier (Delco)																																						V	V	V																		
E	2006	ALL	Body	Climate Control Panel																																									V	V	V	V	V													
E	2006	ALL	Body	Dash Integration Module																																						V	V	V						V	V	V										
E	2006	ALL	Body	Disc Player and Video Display																																																										
E	2006	ALL	Body	Driver Door Switch																																						V	V																			
E	2006	ALL	Body	Driver Door Module																																						V	V	V						V		V	V									
E	2006	ALL	Body	Passenger Door Module																																						V	V	V						V		V	V									
E	2006	ALL	Body	Left Rear Door Module																																						V	V	V									V									
E	2006	ALL	Body	Right Rear Door Module																																						V	V	V									V									
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2006	ALL	Body	Instrument Panel Cluster																																						V	V																			
E	2006	ALL	Body	Lift Gate Module																																						V	V	V								V										
E	2006	ALL	Body	Memory Seat Module																																						V	V	V											V	V						
E	2006	ALL	Body	Personalization																																																					V	V				
E	2006	ALL	Body	Base Radio																																																V										V
E	2006	ALL	Body	Navigation Radio																																																										V
E	2006	ALL	Body	Rear Integration Module																																						V	V	V																	V	
E	2006	ALL	Body	Rear Seat Module																																						V	V	V																		
E	2006	ALL	Body	Remote Function Actuation																																															V											
E	2006	ALL	Body	Supplemental Inflatable Restraint																																						V																				V
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
E	2006	ALL	Body	Vehicle Theft Deterrent																																						V																				
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																												
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																								
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																											V		V	V																												
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																	V	V																								
E	2007	ALL	Chassis	Electronic Brake Control Module																																			V																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
E	2007	ALL	Chassis	Electronic Suspension Control																																																							
E	2007	ALL	Body	Amplifier (Bose)																																																							
E	2007	ALL	Body	Body Control Module			V																																			V	V																
E	2007	ALL	Body	Body Control Module (aux.)																																																						
E	2007	ALL	Body	Digital Radio Receiver																																																						
E	2007	ALL	Body	Driver Door Switch																																					V	V	V																
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																						
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																						
E	2007	ALL	Body	HVAC Control Module																																						V		V															
E	2007	ALL	Body	Instrument Panel Cluster																																																						
E	2007	ALL	Body	Lift Gate Module																																					V																		
E	2007	ALL	Body	Memory Seat Module																																																						
E	2007	ALL	Body	Park Assist Module																																																						
E	2007	ALL	Body	Passenger Door Switch																																					V	V	V																
E	2007	ALL	Body	Passenger Presence System																																					V																		
E	2007	ALL	Body	Radio																																																						
E	2007	ALL	Body	Rear HVAC/RSA																																																						
E	2007	ALL	Body	Rear Seat Module																																					V	V	V																
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																						
E	2007	ALL	Body	Rollover Sensor																																																						
E	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																		
E	2007	ALL	Body	Theft Deterrent Module																																																						
E	2007	ALL	Body	TV Antenna Module																																					V	V	V																
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																										
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																					
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																											V		V	V																										
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																V	V																						
E	2008	ALL	Chassis	Electronic Brake Control Module																																			V																			
E	2008	ALL	Chassis	Electronic Suspension Control																																																						
E	2008	ALL	Body	Amplifier (Bose)																																																						
E	2008	ALL	Body	Body Control Module			V																																			V	V															
E	2008	ALL	Body	Body Control Module (aux.)																																																						
E	2008	ALL	Body	Digital Radio Receiver																																																						
E	2008	ALL	Body	Driver Door Switch																																					V	V	V																
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																						
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																						
E	2008	ALL	Body	HVAC Control Module																																						V		V															
E	2008	ALL	Body	Instrument Panel Cluster																																																						
E	2008	ALL	Body	Lift Gate Module																																					V																		
E	2008	ALL	Body	Memory Seat Module																																																						
E	2008	ALL	Body	Park Assist Module																																																						
E	2008	ALL	Body	Passenger Door Switch																																					V	V	V																
E	2008	ALL	Body	Passenger Presence System																																					V																		
E	2008	ALL	Body	Radio																																																						
E	2008	ALL	Body	Rear HVAC/RSA																																																						
E	2008	ALL	Body	Rear Seat Module																																					V	V	V																
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																						
E	2008	ALL	Body	Rollover Sensor																																																						
E	2008	ALL	Body	Supplemental Inflatable Restraint																																					V																		
E	2008	ALL	Body	Theft Deterrent Module																																																						
E	2008	ALL	Body	TV Antenna Module																																					V	V	V																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																										
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																V	V	V	V		V	V	V	V								V	V	V																						
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																											V		V	V																										
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																	V	V																						
E	2009	ALL	Chassis	Electronic Brake Control Module																																			V																					
E	2009	ALL	Chassis	Electronic Suspension Control																																																								
E	2009	ALL	Body	Amplifier (Bose)																																																							
E	2009	ALL	Body	Body Control Module			V																																				V	V																
E	2009	ALL	Body	Body Control Module (aux.)																																																							
E	2009	ALL	Body	Digital Radio Receiver																																																							
E	2009	ALL	Body	Driver Door Switch																																					V	V	V																	
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																							
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																							
E	2009	ALL	Body	HVAC Control Module																																							V		V															
E	2009	ALL	Body	Instrument Panel Cluster																																																							
E	2009	ALL	Body	Lift Gate Module																																					V																			
E	2009	ALL	Body	Memory Seat Module																																																							
E	2009	ALL	Body	Park Assist Module																																																							
E	2009	ALL	Body	Passenger Door Switch																																					V	V	V																	
E	2009	ALL	Body	Passenger Presence System																																					V																			
E	2009	ALL	Body	Radio																																																							
E	2009	ALL	Body	Rear HVAC/RSA																																																							
E	2009	ALL	Body	Rear Seat Module																																					V	V	V																	
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																							
E	2009	ALL	Body	Rollover Sensor																																																							
E	2009	ALL	Body	Supplemental Inflatable Restraint																																					V																			
E	2009	ALL	Body	Theft Deterrent Module																																																							
E	2009	ALL	Body	TV Antenna Module																																					V	V	V																	
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																									
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																		
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																							
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																							
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																							
K	2004	ALL	Chassis	ESC																																																							
K	2004	ALL	Chassis	Rear Wheel Steering																																																							
K	2004	ALL	Chassis	Tire Pressure Monitor																																																							
K	2004	ALL	Chassis	VSES																																																							
K	2004	ALL	Body	Amplifier (Bose)																																																							
K	2004	ALL	Body	Body Control Module																																					V	V	V																	
K	2004	ALL	Body	CD Changer																																																							
K	2004	ALL	Body	Chime																																																							
K	2004	ALL	Body	Driver Door Module																																					V	V	V																	
K	2004	ALL	Body	Driver Seat Module																																																							
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																							
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																							
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																							
K	2004	ALL	Body	Instrument Panel Cluster																																																							
K	2004	ALL	Body	OnStar																																																							
K	2004	ALL	Body	Passenger Door Module																																					V	V	V																	
K	2004	ALL	Body	Passenger Presence System																																																							
K	2004	ALL	Body	Base Radio																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2004	ALL	Body	Uplevel Radio																																																								
K	2004	ALL	Body	Navigation Radio																																																								
K	2004	ALL	Body	Rear Aux. Climate Module																																					V																			
K	2004	ALL	Body	Rear HVAC																																																								
K	2004	ALL	Body	Rear Seat Audio																																					V																			
K	2004	ALL	Body	Rear Seat Entertainment																																																								
K	2004	ALL	Body	Supplemental Inflatable Restraint																																					V	V																			
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																		
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																								
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																								
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																								
K	2005	ALL	Chassis	ESC																																																								
K	2005	ALL	Chassis	Rear Wheel Steering																																																								
K	2005	ALL	Chassis	Tire Pressure Monitor																																																								
K	2005	ALL	Chassis	VSES																																																								
K	2005	ALL	Body	Amplifier (Bose)																																																								
K	2005	ALL	Body	Body Control Module																																					V	V	V																		
K	2005	ALL	Body	CD Changer																																																								
K	2005	ALL	Body	Chime																																																								
K	2005	ALL	Body	Disc Player and Video Display																																																								
K	2005	ALL	Body	Driver Door Module																																					V	V	V																		
K	2005	ALL	Body	Driver Seat Module																																																								
K	2005	ALL	Body	Generator Battery Control Module																																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																								
K	2005	ALL	Body	Instrument Panel Cluster																																																								
K	2005	ALL	Body	Passenger Door Module																																					V	V	V																		
K	2005	ALL	Body	Passenger Presence System																																																								
K	2005	ALL	Body	Base Radio																																																								
K	2005	ALL	Body	Uplevel Radio																																																								
K	2005	ALL	Body	Navigation Radio																																																								
K	2005	ALL	Body	Rear Aux. Climate Module																																					V																			
K	2005	ALL	Body	Rear HVAC																																																								
K	2005	ALL	Body	Rear Seat Audio																																					V																			
K	2005	ALL	Body	Remote Function Actuation																																																								
K	2005	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																		
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																								
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																								
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																								
K	2006	ALL	Chassis	ESC																																																								
K	2006	ALL	Chassis	Tire Pressure Monitor																																																								
K	2006	ALL	Chassis	VSES																																																								
K	2006	ALL	Body	Amplifier (Bose)																																																								
K	2006	ALL	Body	Body Control Module																																					V	V	V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2006	ALL	Body	CD Changer																																																								
K	2006	ALL	Body	Chime																																																								
K	2006	ALL	Body	Disc Player and Video Display																																																								
K	2006	ALL	Body	Driver Door Module																																					V	V	V																	
K	2006	ALL	Body	Driver Seat Module																																																								
K	2006	ALL	Body	Generator Battery Control Module																																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																								
K	2006	ALL	Body	Instrument Panel Cluster																																																								
K	2006	ALL	Body	Passenger Door Module																																					V	V	V																	
K	2006	ALL	Body	Passenger Presence System																																																								
K	2006	ALL	Body	Base Radio																																																								
K	2006	ALL	Body	Uplevel Radio																																																								
K	2006	ALL	Body	Navigation Radio																																																								
K	2006	ALL	Body	Rear Aux. Climate Module																																					V																			
K	2006	ALL	Body	Rear HVAC																																																								
K	2006	ALL	Body	Rear Seat Audio																																					V																			
K	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																											
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																V	V																								
K	2007	ALL	Chassis	Electronic Brake Control Module																																																								
K	2007	ALL	Chassis	Electronic Suspension Control																																																								
K	2007	ALL	Body	Amplifier (Bose)																																																								
K	2007	ALL	Body	Assist Step Controller																																																								
K	2007	ALL	Body	Body Control Module			V																																			V	V																	
K	2007	ALL	Body	Body Control Module (aux.)																																																								
K	2007	ALL	Body	Digital Radio Receiver																																																								
K	2007	ALL	Body	Driver Door Switch																																					V	V	V																	
K	2007	ALL	Body	HVAC Control Module																																						V		V																
K	2007	ALL	Body	Inside Rear View Mirror Module																																																								
K	2007	ALL	Body	Instrument Panel Cluster																																																								
K	2007	ALL	Body	Lift Gate Module																																					V																			
K	2007	ALL	Body	Memory Seat Module																																																								
K	2007	ALL	Body	Park Assist Module																																																								
K	2007	ALL	Body	Passenger Door Switch																																					V	V	V																	
K	2007	ALL	Body	Passenger Presence System																																					V																			
K	2007	ALL	Body	Radio																																																								
K	2007	ALL	Body	Rear Heated Seat Module																																																								
K	2007	ALL	Body	Rear HVAC/RSA																																																								
K	2007	ALL	Body	Rollover Sensor																																																								
K	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																			
K	2007	ALL	Body	Theft Deterrent Module																																																								
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																											
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																V	V																								
K	2008	ALL	Chassis	Electronic Brake Control Module																																			V																					
K	2008	ALL	Chassis	Electronic Suspension Control																																																								
K	2008	ALL	Chassis	Trailer Brake Control Module																																																								
K	2008	ALL	Body	Amplifier (Bose)																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2008	ALL	Body	Assist Step Controller																																																								
K	2008	ALL	Body	Body Control Module			V																																			V	V																	
K	2008	ALL	Body	Body Control Module (aux.)																																																								
K	2008	ALL	Body	Digital Radio Receiver																																																								
K	2008	ALL	Body	Driver Door Switch																																					V	V	V																	
K	2008	ALL	Body	HVAC Control Module																																						V		V																
K	2008	ALL	Body	Inside Rear View Mirror Module																																																								
K	2008	ALL	Body	Instrument Panel Cluster																																																								
K	2008	ALL	Body	Lift Gate Module																																					V																			
K	2008	ALL	Body	Memory Seat Module																																																								
K	2008	ALL	Body	Park Assist Module																																																								
K	2008	ALL	Body	Passenger Door Switch																																					V	V	V																	
K	2008	ALL	Body	Passenger Presence System																																					V																			
K	2008	ALL	Body	Radio																																																								
K	2008	ALL	Body	Rear Heated Seat Module																																																								
K	2008	ALL	Body	Rear HVAC/RSA																																																								
K	2008	ALL	Body	Rollover Sensor																																																								
K	2008	ALL	Body	Supplemental Inflatable Restraint																																					V																			
K	2008	ALL	Body	Theft Deterrent Module																																																								
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
K	2009	ALL	Chassis	Electronic Brake Control Module																																			V																					
K	2009	ALL	Chassis	Electronic Suspension Control																																																								
K	2009	ALL	Chassis	Trailer Brake Control Module																																																								
K	2009	ALL	Body	Amplifier (Bose)																																																								
K	2009	ALL	Body	Assist Step Controller																																																								
K	2009	ALL	Body	Body Control Module			V																																			V	V																	
K	2009	ALL	Body	Body Control Module (aux.)																																																								
K	2009	ALL	Body	Digital Radio Receiver																																																								
K	2009	ALL	Body	Driver Door Switch																																					V	V	V																	
K	2009	ALL	Body	HVAC Control Module																																						V		V																
K	2009	ALL	Body	Inside Rear View Mirror Module																																																								
K	2009	ALL	Body	Instrument Panel Cluster																																																								
K	2009	ALL	Body	Left Side Object Detection Module																																																								
K	2009	ALL	Body	Lift Gate Module																																					V																			
K	2009	ALL	Body	Memory Seat Module																																																								
K	2009	ALL	Body	Park Assist Module																																																								
K	2009	ALL	Body	Passenger Door Switch																																					V	V	V																	
K	2009	ALL	Body	Passenger Presence System																																					V																			
K	2009	ALL	Body	Radio																																																								
K	2009	ALL	Body	Rear Heated Seat Module																																																								
K	2009	ALL	Body	Rear HVAC/RSA																																																								
K	2009	ALL	Body	Right Side Object Detection Module																																																								
K	2009	ALL	Body	Rollover Sensor																																																								
K	2009	ALL	Body	Supplemental Inflatable Restraint																																					V																			
K	2009	ALL	Body	Theft Deterrent Module																																																								
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																										
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																	V	V																						
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																V	V																							
K	2010	ALL	Chassis	Electronic Brake Control Module																																			V																						
K	2010	ALL	Chassis	Electronic Suspension Control																																																								
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	ALL	Body	Amplifier (Bose)																																																								
K	2010	ALL	Body	Assist Step Controller																																																								
K	2010	ALL	Body	Body Control Module			V																																			V	V																		
K	2010	ALL	Body	Body Control Module (aux.)																																																								
K	2010	ALL	Body	Digital Radio Receiver																																																								
K	2010	ALL	Body	Driver Door Switch																																					V	V	V																		
K	2010	ALL	Body	HVAC Control Module																																						V		V																	
K	2010	ALL	Body	Inside Rear View Mirror Module																																																								
K	2010	ALL	Body	Instrument Panel Cluster																																																								
K	2010	ALL	Body	Left Side Object Detection Module																																																								
K	2010	ALL	Body	Lift Gate Module																																					V																			
K	2010	ALL	Body	Memory Seat Module																																																								
K	2010	ALL	Body	Park Assist Module																																																								
K	2010	ALL	Body	Passenger Door Switch																																					V	V	V																		
K	2010	ALL	Body	Passenger Presence System																																					V																			
K	2010	ALL	Body	Radio																																																								
K	2010	ALL	Body	Rear Heated Seat Module																																																								
K	2010	ALL	Body	Rear HVAC/RSA																																																								
K	2010	ALL	Body	Right Side Object Detection Module																																																								
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2010	ALL	Body	Theft Deterrent Module																																																								
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																								
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																								
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																								
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																								
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																								
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																								
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																								
N	2010	SRX	Chassis	Electronic Brake Control Module																																																								
N	2010	SRX	Chassis	Parking Brake Control Module																																																								
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																								
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																																								
N	2010	SRX	Chassis	Suspension Control Module																																																								
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
N	2010	SRX	Body	Passenger Presence Module																																																								
N	2010	SRX	Body	Instrument Cluster																																																								
N	2010	SRX	Body	Headlamp Control Module																																																								
N	2010	SRX	Body	Trailer Interface Control Module																																																								
N	2010	SRX	Body	Radio																																																								
N	2010	SRX	Body	Rear Audio Control Module																																																								
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																								
N	2010	SRX	Body	Multimedia Player Interface Module																																																								
N	2010	SRX	Body	Mobile Telephone Control Module																																																								
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																									
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																									
N	2010	SRX	Body	Liftgate Control Module																																																									
N	2010	SRX	Body	Seat Memory Control Module																																																									
N	2010	SRX	Body	Front Seat Heating Control Module																																																									
N	2010	SRX	Body	Rear Seat Heating Control Module																																																									
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																									
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
N	2010	SRX	Body	Parking Assist Control Module																																																									
N	2010	SRX	Body	Steering Column Lock Control Module																																																									
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																									
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																									
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																									
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																									
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																									
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																									
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2011	SRX	Chassis	Electronic Brake Control Module																																																									
N	2011	SRX	Chassis	Parking Brake Control Module																																																									
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2011	SRX	Chassis	Suspension Control Module																																																									
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2011	SRX	Body	Passenger Presence Module																																																									
N	2011	SRX	Body	Instrument Cluster																																																									
N	2011	SRX	Body	Headlamp Control Module																																																									
N	2011	SRX	Body	Trailer Interface Control Module																																																									
N	2011	SRX	Body	Radio																																																									
N	2011	SRX	Body	Rear Audio Control Module																																																									
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																									
N	2011	SRX	Body	Multimedia Player Interface Module																																																									
N	2011	SRX	Body	Mobile Telephone Control Module																																																									
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																									
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																									
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																									
N	2011	SRX	Body	Liftgate Control Module																																																									
N	2011	SRX	Body	Seat Memory Control Module																																																									
N	2011	SRX	Body	Front Seat Heating Control Module																																																									
N	2011	SRX	Body	Rear Seat Heating Control Module																																																									
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																									
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
N	2011	SRX	Body	Parking Assist Control Module																																																									
N	2011	SRX	Body	Steering Column Lock Control Module																																																									
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																									
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																									
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2012	SRX	Chassis	Electronic Brake Control Module																																																									
N	2012	SRX	Chassis	Parking Brake Control Module																																																									
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2012	SRX	Chassis	Suspension Control Module																																																									
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2012	SRX	Body	Passenger Presence Module																																																									
N	2012	SRX	Body	Instrument Cluster																																																									
N	2012	SRX	Body	Headlamp Control Module																																																									
N	2012	SRX	Body	Trailer Interface Control Module																																																									
N	2012	SRX	Body	Radio																																																									
N	2012	SRX	Body	Rear Audio Control Module																																																									
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																									
N	2012	SRX	Body	Multimedia Player Interface Module																																																									
N	2012	SRX	Body	Mobile Telephone Control Module																																																									
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																																									
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																																									
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																									
N	2012	SRX	Body	Liftgate Control Module																																																									
N	2012	SRX	Body	Seat Memory Control Module																																																									
N	2012	SRX	Body	Front Seat Heating Control Module																																																									
N	2012	SRX	Body	Rear Seat Heating Control Module																																																									
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																									
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
N	2012	SRX	Body	Parking Assist Control Module																																																									
N	2012	SRX	Body	Steering Column Lock Control Module																																																									
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2013	SRX	Chassis	Electronic Brake Control Module																																																									
N	2013	SRX	Chassis	Parking Brake Control Module																																																									
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2013	SRX	Chassis	Suspension Control Module																																																									
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2013	SRX	Body	Passenger Presence Module																																																									
N	2013	SRX	Body	Instrument Cluster																																																									
N	2013	SRX	Body	Radio/HVAC Control																																																									
N	2013	SRX	Body	Active Safety Control Module	V																																																								
N	2013	SRX	Body	Headlamp Control Module																																																									
N	2013	SRX	Body	Trailer Interface Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
N	2013	SRX	Body	Radio																																																								
N	2013	SRX	Body	Amplifier																																																								
N	2013	SRX	Body	Media Disc Player																																																								
N	2013	SRX	Body	Human Machine Interface Control Module																																																								
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																																								
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																																								
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																								
N	2013	SRX	Body	Liftgate Control Module																																																								
N	2013	SRX	Body	Seat Memory Control Module																																																								
N	2013	SRX	Body	Rear Seat Heating Control Module																																																								
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																								
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																								
N	2013	SRX	Body	Right Side Object Detection Control Module																																																								
N	2013	SRX	Body	Left Side Object Detection Control Module																																																								
N	2013	SRX	Body	Parking Assist Control Module																																																								
N	2013	SRX	Body	Frontview Camera Module																																																								
N	2013	SRX	Body	Steering Column Lock Control Module																																																								
N	2013	SRX	Body	Long Range Radar Sensor Module		V																																																						
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																								
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																								
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																								
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																								
N	2014	SRX	Chassis	Electronic Brake Control Module																																																								
N	2014	SRX	Chassis	Parking Brake Control Module																																																								
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																								
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																																								
N	2014	SRX	Chassis	Suspension Control Module																																																								
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
N	2014	SRX	Body	Passenger Presence Module																																																								
N	2014	SRX	Body	Instrument Cluster																																																								
N	2014	SRX	Body	Radio/HVAC Control																																																								
N	2014	SRX	Body	Active Safety Control Module	V																																																							
N	2014	SRX	Body	Headlamp Control Module																																																								
N	2014	SRX	Body	Trailer Interface Control Module																																																								
N	2014	SRX	Body	Radio																																																								
N	2014	SRX	Body	Amplifier																																																								
N	2014	SRX	Body	Media Disc Player																																																								
N	2014	SRX	Body	Human Machine Interface Control Module																																																								
N	2014	SRX	Body	Navigation Control Module																																																								
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																								
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																																								
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																								
N	2014	SRX	Body	Liftgate Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																									
N	2014	SRX	Body	Rear Seat Heating Control Module																																																										
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2014	SRX	Body	Right Side Object Detection Control Module																																																										
N	2014	SRX	Body	Left Side Object Detection Control Module																																																										
N	2014	SRX	Body	Parking Assist Control Module																																																										
N	2014	SRX	Body	Frontview Camera Module																																																										
N	2014	SRX	Body	Steering Column Lock Control Module																																																										
N	2014	SRX	Body	Long Range Radar Sensor Module		V																																																								
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																										
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2015	SRX	Chassis	Electronic Brake Control Module																																																										
N	2015	SRX	Chassis	Parking Brake Control Module																																																										
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2015	SRX	Chassis	Suspension Control Module																																																										
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2015	SRX	Body	Passenger Presence Module																																																										
N	2015	SRX	Body	Instrument Cluster																																																										
N	2015	SRX	Body	Radio/HVAC Control																																																										
N	2015	SRX	Body	Active Safety Control Module	V																																																									
N	2015	SRX	Body	Headlamp Control Module																																																										
N	2015	SRX	Body	Trailer Interface Control Module																																																										
N	2015	SRX	Body	Radio																																																										
N	2015	SRX	Body	Amplifier																																																										
N	2015	SRX	Body	Rear Audio Control Module																																																										
N	2015	SRX	Body	Media Disc Player																																																										
N	2015	SRX	Body	Human Machine Interface Control Module																																																										
N	2015	SRX	Body	Navigation Control Module																																																										
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																										
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2015	SRX	Body	Liftgate Control Module																																																										
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2015	SRX	Body	Rear Seat Heating Control Module																																																										
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2015	SRX	Body	Right Side Object Detection Control Module																																																										
N	2015	SRX	Body	Left Side Object Detection Control Module																																																										
N	2015	SRX	Body	Parking Assist Control Module																																																										
N	2015	SRX	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
N	2015	SRX	Body	Steering Column Lock Control Module																																																								
N	2015	SRX	Body	Long Range Radar Sensor Module		V																																																							
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																									
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																									
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																									
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2016	SRX	Chassis	Electronic Brake Control Module																																																									
N	2016	SRX	Chassis	Parking Brake Control Module																																																									
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2016	SRX	Chassis	Suspension Control Module																																																									
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2016	SRX	Body	Passenger Presence Module																																																									
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																									
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																																									
N	2016	SRX	Body	Radio/HVAC Control																																																									
N	2016	SRX	Body	Active Safety Control Module	V																																																								
N	2016	SRX	Body	Headlamp Control Module																																																									
N	2016	SRX	Body	Trailer Interface Control Module																																																									
N	2016	SRX	Body	Radio																																																									
N	2016	SRX	Body	Amplifier																																																									
N	2016	SRX	Body	Rear Audio Control Module																																																									
N	2016	SRX	Body	Media Disc Player																																																									
N	2016	SRX	Body	Human Machine Interface Control Module																																																									
N	2016	SRX	Body	Navigation Control Module																																																									
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																									
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																																									
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																									
N	2016	SRX	Body	Liftgate Control Module																																																									
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																									
N	2016	SRX	Body	Rear Seat Heating Control Module																																																									
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																									
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
N	2016	SRX	Body	Right Side Object Detection Control Module																																																									
N	2016	SRX	Body	Left Side Object Detection Control Module																																																									
N	2016	SRX	Body	Parking Assist Control Module																																																									
N	2016	SRX	Body	Frontview Camera Module																																																									
N	2016	SRX	Body	Steering Column Lock Control Module																																																									
N	2016	SRX	Body	Long Range Radar Sensor Module		V																																																							
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																									
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																									
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																									
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																											
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																V	V																						
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																										V		V	V																										
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																							
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																V	V																						
3	2011	ALL	Chassis	Electronic Brake Control Module																																			V																				
3	2011	ALL	Chassis	Electronic Suspension Control																																																						
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																						
3	2011	ALL	Body	Amplifier (Bose)																																																						
3	2011	ALL	Body	Assist Step Controller																																																					
3	2011	ALL	Body	Body Control Module			V																																			V	V																
3	2011	ALL	Body	Body Control Module (aux.)																																																						
3	2011	ALL	Body	Digital Radio Receiver																																																						
3	2011	ALL	Body	Driver Door Switch																																					V	V	V																	
3	2011	ALL	Body	HVAC Control Module																																						V		V																
3	2011	ALL	Body	Inside Rear View Mirror Module																																																						
3	2011	ALL	Body	Instrument Panel Cluster																																																						
3	2011	ALL	Body	Left Side Object Detection Module																																																						
3	2011	ALL	Body	Lift Gate Module																																					V																			
3	2011	ALL	Body	Memory Seat Module																																																						
3	2011	ALL	Body	Park Assist Module																																																						
3	2011	ALL	Body	Passenger Door Switch																																					V	V	V																	
3	2011	ALL	Body	Passenger Presence System																																					V																		
3	2011	ALL	Body	Radio																																																						
3	2011	ALL	Body	Rear Heated Seat Module																																																						
3	2011	ALL	Body	Rear HVAC/RSA																																																						
3	2011	ALL	Body	Right Side Object Detection Module																																																						
3	2011	ALL	Body	Supplemental Inflatable Restraint																																																						
3	2011	ALL	Body	Theft Deterrent Module																																																						
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																										V		V	V																										
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																						
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																V	V																						
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																										V		V	V																										
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																						
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																V	V																						
3	2012	ALL	Chassis	Electronic Brake Control Module																																			V																				
3	2012	ALL	Chassis	Electronic Suspension Control																																																						
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																						
3	2012	ALL	Body	Amplifier (Bose)																																																						
3	2012	ALL	Body	Assist Step Controller																																																					
3	2012	ALL	Body	Body Control Module			V																																			V	V																
3	2012	ALL	Body	Body Control Module (aux.)																																																						
3	2012	ALL	Body	Driver Door Switch																																					V	V	V																	
3	2012	ALL	Body	HVAC Control Module																																						V		V																
3	2012	ALL	Body	Inside Rear View Mirror Module																																																						
3	2012	ALL	Body	Instrument Panel Cluster																																																						
3	2012	ALL	Body	Left Side Object Detection Module																																																						
3	2012	ALL	Body	Lift Gate Module																																					V																			
3	2012	ALL	Body	Memory Seat Module																																																						
3	2012	ALL	Body	Park Assist Module																																																						
3	2012	ALL	Body	Passenger Door Switch																																					V	V	V																	
3	2012	ALL	Body	Passenger Presence System																																					V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
3	2012	ALL	Body	Radio																																																								
3	2012	ALL	Body	Rear Heated Seat Module																																																								
3	2012	ALL	Body	Rear HVAC/RSA																																																								
3	2012	ALL	Body	Right Side Object Detection Module																																																								
3	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
3	2012	ALL	Body	Theft Deterrent Module																																																								
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																												V		V	V																									
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																	V	V																						
3	2013	ALL	Chassis	Electronic Brake Control Module																																			V																					
3	2013	ALL	Chassis	Electronic Suspension Control																																																								
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																								
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																								
3	2013	ALL	Body	Amplifier (Bose)																																																								
3	2013	ALL	Body	Assist Step Controller																																																								
3	2013	ALL	Body	Body Control Module			V																																				V	V																
3	2013	ALL	Body	Body Control Module (aux.)																																																								
3	2013	ALL	Body	Driver Door Switch																																					V	V	V																	
3	2013	ALL	Body	HVAC Control Module																																						V		V																
3	2013	ALL	Body	Inside Rear View Mirror Module																																																								
3	2013	ALL	Body	Instrument Panel Cluster																																																								
3	2013	ALL	Body	Left Side Object Detection Module																																																								
3	2013	ALL	Body	Lift Gate Module																																					V																			
3	2013	ALL	Body	Memory Seat Module																																																								
3	2013	ALL	Body	Park Assist Module																																																								
3	2013	ALL	Body	Passenger Door Switch																																					V	V	V																	
3	2013	ALL	Body	Passenger Presence System																																					V																			
3	2013	ALL	Body	Radio																																																								
3	2013	ALL	Body	Rear Heated Seat Module																																																								
3	2013	ALL	Body	Rear HVAC/RSA																																																								
3	2013	ALL	Body	Right Side Object Detection Module																																																								
3	2013	ALL	Body	Supplemental Inflatable Restraint																																																								
3	2013	ALL	Body	Theft Deterrent Module																																																								
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																								
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																								
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																								
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																								
3	2014	Escalade	Chassis	Suspension Control Module																																																								
3	2014	Escalade	Body	Body Control Module																																																								
3	2014	Escalade	Body	Auxiliary Body Control Module																																																								
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
3	2014	Escalade	Body	Passenger Presence Module																																																								
3	2014	Escalade	Body	Instrument Cluster																																																								
3	2014	Escalade	Body	Radio																																																								
3	2014	Escalade	Body	Amplifier																																																								
3	2014	Escalade	Body	Rear Audio Control Module																																																								
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																								
3	2014	Escalade	Body	Personal Audio Link Control Module																																																								
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																								
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
3	2014	Escalade	Body	HVAC Control Module																																																									
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																										
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																										
3	2014	Escalade	Body	Liftgate Control Module																																																										
3	2014	Escalade	Body	Seat Memory Control Module																																																										
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																										
3	2014	Escalade	Body	Assist Step Control Module																																																										
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																										
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																										
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																										
3	2014	Escalade	Body	Parking Assist Control Module																																																										
3	2014	Escalade	Body	Theft Deterrent Module																																																										
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																										
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2014	Escalade ESV	Body	Body Control Module																																																										
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																										
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2014	Escalade ESV	Body	Passenger Presence Module																																																										
3	2014	Escalade ESV	Body	Instrument Cluster																																																										
3	2014	Escalade ESV	Body	Radio																																																										
3	2014	Escalade ESV	Body	Amplifier																																																										
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																										
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																										
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																										
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																										
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2014	Escalade ESV	Body	HVAC Control Module																																																										
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																										
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																										
3	2014	Escalade ESV	Body	Liftgate Control Module																																																										
3	2014	Escalade ESV	Body	Seat Memory Control Module																																																										
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																										
3	2014	Escalade ESV	Body	Assist Step Control Module																																																										
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																										
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																										
3	2014	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2014	Escalade ESV	Body	Theft Deterrent Module																																																										
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																										
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																										
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																							
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																							
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																						
3	2015	Escalade	Chassis	Electronic Brake Control Module																																																						
3	2015	Escalade	Chassis	Parking Brake Control Module																																																						
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																						
3	2015	Escalade	Chassis	Power Steering Control Module																																																						
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																						
3	2015	Escalade	Chassis	Suspension Control Module																																																						
3	2015	Escalade	Body	Body Control Module																																																						
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
3	2015	Escalade	Body	Passenger Presence Module																																																						
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left				V	V																																																		
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right				V	V																																																		
3	2015	Escalade	Body	Instrument Cluster																																																						
3	2015	Escalade	Body	Radio/HVAC Control																																																						
3	2015	Escalade	Body	Active Safety Control Module	V																																																					
3	2015	Escalade	Body	Video Processing Control Module								V	V	V	V	V																																											
3	2015	Escalade	Body	Radio																																																						
3	2015	Escalade	Body	Amplifier																																																						
3	2015	Escalade	Body	Media Disc Player																																																						
3	2015	Escalade	Body	Human Machine Interface Control Module																																																						
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																						
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																						
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																						
3	2015	Escalade	Body	HVAC Control Module																																																						
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																						
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																						
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																						
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																						
3	2015	Escalade	Body	Keyless Entry Control Module																																																						
3	2015	Escalade	Body	Assist Step Control Module																																																						
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																						
3	2015	Escalade	Body	Parking Assist Control Module																																																						
3	2015	Escalade	Body	Frontview Camera Module																																																						
3	2015	Escalade	Body	Steering Column Lock Control Module																																																						
3	2015	Escalade	Body	Battery Energy Control Module																																																						
3	2015	Escalade	Body	Long Range Radar Sensor Module		V																																																				
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																						
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																						
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																						
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																						
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																						
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																						
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																						
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																						
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																						
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																						
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																						
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																						
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																																										
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2015	Escalade ESV	Body	Body Control Module																																																										
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2015	Escalade ESV	Body	Passenger Presence Module																																																										
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left				V	V																																																				
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right				V	V																																																				
3	2015	Escalade ESV	Body	Instrument Cluster																																																										
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																										
3	2015	Escalade ESV	Body	Active Safety Control Module	V																																																									
3	2015	Escalade ESV	Body	Video Processing Control Module								V	V	V	V	V																																														
3	2015	Escalade ESV	Body	Radio																																																										
3	2015	Escalade ESV	Body	Amplifier																																																										
3	2015	Escalade ESV	Body	Media Disc Player																																																										
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2015	Escalade ESV	Body	HVAC Control Module																																																										
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																										
3	2015	Escalade ESV	Body	Assist Step Control Module																																																										
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2015	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2015	Escalade ESV	Body	Frontview Camera Module																																																										
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																										
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module		V																																																								
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2016	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2016	Escalade	Chassis	Parking Brake Control Module																																																										
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2016	Escalade	Chassis	Power Steering Control Module																																																										
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2016	Escalade	Chassis	Suspension Control Module																																																										
3	2016	Escalade	Body	Body Control Module																																																										
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
3	2016	Escalade	Body	Passenger Presence Module																																																								
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left				V	V																																																			
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right				V	V																																																				
3	2016	Escalade	Body	Instrument Cluster																																																								
3	2016	Escalade	Body	Radio/HVAC Control																																																								
3	2016	Escalade	Body	Active Safety Control Module	V																																																							
3	2016	Escalade	Body	Video Processing Control Module								V	V	V	V	V																																													
3	2016	Escalade	Body	Radio																																																								
3	2016	Escalade	Body	Amplifier																																																								
3	2016	Escalade	Body	Media Disc Player																																																								
3	2016	Escalade	Body	Human Machine Interface Control Module																																																								
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																																								
3	2016	Escalade	Body	HVAC Control Module																																																								
3	2016	Escalade	Body	Liftgate Control Module																																																								
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																								
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																								
3	2016	Escalade	Body	Keyless Entry Control Module																																																								
3	2016	Escalade	Body	Assist Step Control Module																																																								
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																								
3	2016	Escalade	Body	Parking Assist Control Module																																																								
3	2016	Escalade	Body	Frontview Camera Module																																																								
3	2016	Escalade	Body	Steering Column Lock Control Module																																																								
3	2016	Escalade	Body	Long Range Radar Sensor Module		V																																																						
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																								
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																								
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																								
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																								
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																								
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																								
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																								
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																																								
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																								
3	2016	Escalade ESV	Chassis	Suspension Control Module																																																								
3	2016	Escalade ESV	Body	Body Control Module																																																								
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
3	2016	Escalade ESV	Body	Passenger Presence Module																																																								
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left				V	V																																																			
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right				V	V																																																			
3	2016	Escalade ESV	Body	Instrument Cluster																																																								
3	2016	Escalade ESV	Body	Radio Control																																																								
3	2016	Escalade ESV	Body	HVAC Control																																																								
3	2016	Escalade ESV	Body	Active Safety Control Module	V																																																							
3	2016	Escalade ESV	Body	Video Processing Control Module								V	V	V	V	V																																													
3	2016	Escalade ESV	Body	Radio																																																								
3	2016	Escalade ESV	Body	Amplifier																																																								
3	2016	Escalade ESV	Body	Media Disc Player																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																							
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																							
3	2016	Escalade ESV	Body	HVAC Control Module																																																							
3	2016	Escalade ESV	Body	Liftgate Control Module																																																						
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																						
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																						
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																						
3	2016	Escalade ESV	Body	Assist Step Control Module																																																						
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																						
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																						
3	2016	Escalade ESV	Body	Frontview Camera Module																																																						
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																						
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module		V																																																					
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																						
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																						
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																						
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																						
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																									
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																						
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																	V	V																					
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																									
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																						
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																					
4	2011	ALL	Chassis	Electronic Brake Control Module																																			V																				
4	2011	ALL	Chassis	Electronic Suspension Control																																																						
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																						
4	2011	ALL	Body	Amplifier (Bose)																																																						
4	2011	ALL	Body	Assist Step Controller																																																					
4	2011	ALL	Body	Body Control Module			V																																			V	V															
4	2011	ALL	Body	Body Control Module (aux.)																																																						
4	2011	ALL	Body	Driver Door Switch																																					V	V	V															
4	2011	ALL	Body	HVAC Control Module																																						V		V														
4	2011	ALL	Body	Inside Rear View Mirror Module																																																						
4	2011	ALL	Body	Instrument Panel Cluster																																																						
4	2011	ALL	Body	Left Side Object Detection Module																																																						
4	2011	ALL	Body	Lift Gate Module																																					V																		
4	2011	ALL	Body	Memory Seat Module																																																						
4	2011	ALL	Body	Park Assist Module																																																						
4	2011	ALL	Body	Passenger Door Switch																																					V	V	V															
4	2011	ALL	Body	Passenger Presence System																																					V																		
4	2011	ALL	Body	Radio																																																						
4	2011	ALL	Body	Rear Heated Seat Module																																																						
4	2011	ALL	Body	Rear HVAC/RSA																																																						
4	2011	ALL	Body	Right Side Object Detection Module																																																						
4	2011	ALL	Body	Supplemental Inflatable Restraint																																																						
4	2011	ALL	Body	Theft Deterrent Module																																																						
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																									
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																						
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																	V	V																					
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																									
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																V	V																						
4	2012	ALL	Chassis	Electronic Brake Control Module																																			V																				
4	2012	ALL	Chassis	Electronic Suspension Control																																																							
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																							
4	2012	ALL	Body	Amplifier (Bose)																																																							
4	2012	ALL	Body	Assist Step Controller																																																							
4	2012	ALL	Body	Body Control Module			V																																				V	V																
4	2012	ALL	Body	Body Control Module (aux.)																																																							
4	2012	ALL	Body	Driver Door Switch																																					V	V	V																	
4	2012	ALL	Body	HVAC Control Module																																						V		V																
4	2012	ALL	Body	Inside Rear View Mirror Module																																																							
4	2012	ALL	Body	Instrument Panel Cluster																																																							
4	2012	ALL	Body	Left Side Object Detection Module																																																							
4	2012	ALL	Body	Lift Gate Module																																					V																			
4	2012	ALL	Body	Memory Seat Module																																																							
4	2012	ALL	Body	Park Assist Module																																																							
4	2012	ALL	Body	Passenger Door Switch																																					V	V	V																	
4	2012	ALL	Body	Passenger Presence System																																					V																			
4	2012	ALL	Body	Radio																																																							
4	2012	ALL	Body	Rear Heated Seat Module																																																							
4	2012	ALL	Body	Rear HVAC/RSA																																																							
4	2012	ALL	Body	Right Side Object Detection Module																																																							
4	2012	ALL	Body	Supplemental Inflatable Restraint																																																							
4	2012	ALL	Body	Theft Deterrent Module																																																							
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																										
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																							
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																V	V																						
4	2013	ALL	Chassis	Electronic Brake Control Module																																			V																				
4	2013	ALL	Chassis	Electronic Suspension Control																																																							
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																							
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																							
4	2013	ALL	Body	Amplifier (Bose)																																																							
4	2013	ALL	Body	Assist Step Controller																																																							
4	2013	ALL	Body	Body Control Module			V																																			V	V																
4	2013	ALL	Body	Body Control Module (aux.)																																																							
4	2013	ALL	Body	Driver Door Switch																																					V	V	V																	
4	2013	ALL	Body	HVAC Control Module																																						V		V																
4	2013	ALL	Body	Inside Rear View Mirror Module																																																							
4	2013	ALL	Body	Instrument Panel Cluster																																																							
4	2013	ALL	Body	Left Side Object Detection Module																																																							
4	2013	ALL	Body	Lift Gate Module																																					V																			
4	2013	ALL	Body	Memory Seat Module																																																							
4	2013	ALL	Body	Park Assist Module																																																							
4	2013	ALL	Body	Passenger Door Switch																																					V	V	V																	
4	2013	ALL	Body	Passenger Presence System																																					V																			
4	2013	ALL	Body	Radio																																																							
4	2013	ALL	Body	Rear Heated Seat Module																																																							
4	2013	ALL	Body	Rear HVAC/RSA																																																							
4	2013	ALL	Body	Right Side Object Detection Module																																																							
4	2013	ALL	Body	Supplemental Inflatable Restraint																																																							
4	2013	ALL	Body	Theft Deterrent Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																									
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
4	2014	Escalade	Chassis	Electronic Brake Control Module																																																									
4	2014	Escalade	Chassis	Suspension Control Module																																																									
4	2014	Escalade	Body	Body Control Module																																																									
4	2014	Escalade	Body	Auxiliary Body Control Module																																																									
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
4	2014	Escalade	Body	Passenger Presence Module																																																									
4	2014	Escalade	Body	Instrument Cluster																																																									
4	2014	Escalade	Body	Radio																																																									
4	2014	Escalade	Body	Amplifier																																																									
4	2014	Escalade	Body	Rear Audio Control Module																																																									
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																																									
4	2014	Escalade	Body	Personal Audio Link Control Module																																																									
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																									
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																									
4	2014	Escalade	Body	HVAC Control Module																																																									
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																									
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																									
4	2014	Escalade	Body	Liftgate Control Module																																																									
4	2014	Escalade	Body	Seat Memory Control Module																																																									
4	2014	Escalade	Body	Rear Seat Heating Control Module																																																									
4	2014	Escalade	Body	Assist Step Control Module																																																									
4	2014	Escalade	Body	Right Side Object Detection Control Module																																																									
4	2014	Escalade	Body	Left Side Object Detection Control Module																																																									
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																																									
4	2014	Escalade	Body	Parking Assist Control Module																																																									
4	2014	Escalade	Body	Theft Deterrent Module																																																									
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																									
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																									
4	2014	Escalade ESV	Chassis	Suspension Control Module																																																									
4	2014	Escalade ESV	Body	Body Control Module																																																									
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																									
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
4	2014	Escalade ESV	Body	Passenger Presence Module																																																									
4	2014	Escalade ESV	Body	Instrument Cluster																																																									
4	2014	Escalade ESV	Body	Radio																																																									
4	2014	Escalade ESV	Body	Amplifier																																																									
4	2014	Escalade ESV	Body	Rear Audio Control Module																																																									
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																									
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																									
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																									
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																									
4	2014	Escalade ESV	Body	HVAC Control Module																																																									
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																									
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
4	2014	Escalade ESV	Body	Liftgate Control Module																																																								
4	2014	Escalade ESV	Body	Seat Memory Control Module																																																								
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																								
4	2014	Escalade ESV	Body	Assist Step Control Module																																																								
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																								
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																								
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																								
4	2014	Escalade ESV	Body	Parking Assist Control Module																																																								
4	2014	Escalade ESV	Body	Theft Deterrent Module																																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																								
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																								
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																								
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																								
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																								
4	2015	Escalade	Chassis	Electronic Brake Control Module																																																								
4	2015	Escalade	Chassis	Parking Brake Control Module																																																								
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																								
4	2015	Escalade	Chassis	Power Steering Control Module																																																								
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																								
4	2015	Escalade	Chassis	Suspension Control Module																																																								
4	2015	Escalade	Body	Body Control Module																																																								
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
4	2015	Escalade	Body	Passenger Presence Module																																																								
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left				V	V																																																		
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right				V	V																																																		
4	2015	Escalade	Body	Instrument Cluster																																																								
4	2015	Escalade	Body	Radio/HVAC Control																																																								
4	2015	Escalade	Body	Active Safety Control Module	V																																																							
4	2015	Escalade	Body	Video Processing Control Module								V	V	V	V	V																																													
4	2015	Escalade	Body	Radio																																																								
4	2015	Escalade	Body	Amplifier																																																								
4	2015	Escalade	Body	Media Disc Player																																																								
4	2015	Escalade	Body	Human Machine Interface Control Module																																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																								
4	2015	Escalade	Body	HVAC Control Module																																																								
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																								
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																								
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																								
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																								
4	2015	Escalade	Body	Keyless Entry Control Module																																																								
4	2015	Escalade	Body	Assist Step Control Module																																																								
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
4	2015	Escalade	Body	Parking Assist Control Module																																																										
4	2015	Escalade	Body	Frontview Camera Module																																																											
4	2015	Escalade	Body	Steering Column Lock Control Module																																																										
4	2015	Escalade	Body	Battery Energy Control Module																																																										
4	2015	Escalade	Body	Long Range Radar Sensor Module		V																																																								
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																										
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																																										
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2015	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2015	Escalade ESV	Body	Body Control Module																																																										
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2015	Escalade ESV	Body	Passenger Presence Module																																																										
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left				V	V																																																				
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right				V	V																																																				
4	2015	Escalade ESV	Body	Instrument Cluster																																																										
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																										
4	2015	Escalade ESV	Body	Active Safety Control Module	V																																																									
4	2015	Escalade ESV	Body	Video Processing Control Module								V	V	V	V	V																																														
4	2015	Escalade ESV	Body	Radio																																																										
4	2015	Escalade ESV	Body	Amplifier																																																										
4	2015	Escalade ESV	Body	Media Disc Player																																																										
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2015	Escalade ESV	Body	HVAC Control Module																																																										
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																										
4	2015	Escalade ESV	Body	Assist Step Control Module																																																										
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
4	2015	Escalade ESV	Body	Parking Assist Control Module																																																										
4	2015	Escalade ESV	Body	Frontview Camera Module																																																										
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module		V																																																							
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																									
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																									
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																									
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																									
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
4	2016	Escalade	Chassis	Electronic Brake Control Module																																																									
4	2016	Escalade	Chassis	Parking Brake Control Module																																																									
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																									
4	2016	Escalade	Chassis	Power Steering Control Module																																																									
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																									
4	2016	Escalade	Chassis	Suspension Control Module																																																									
4	2016	Escalade	Body	Body Control Module																																																									
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
4	2016	Escalade	Body	Passenger Presence Module																																																									
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left				V	V																																																				
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right				V	V																																																				
4	2016	Escalade	Body	Instrument Cluster																																																									
4	2016	Escalade	Body	Radio/HVAC Control																																																									
4	2016	Escalade	Body	Active Safety Control Module	V																																																								
4	2016	Escalade	Body	Video Processing Control Module								V	V	V	V	V																																													
4	2016	Escalade	Body	Radio																																																									
4	2016	Escalade	Body	Amplifier																																																									
4	2016	Escalade	Body	Media Disc Player																																																									
4	2016	Escalade	Body	Human Machine Interface Control Module																																																									
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																																									
4	2016	Escalade	Body	HVAC Control Module																																																									
4	2016	Escalade	Body	Liftgate Control Module																																																									
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																									
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																									
4	2016	Escalade	Body	Keyless Entry Control Module																																																									
4	2016	Escalade	Body	Assist Step Control Module																																																									
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																									
4	2016	Escalade	Body	Parking Assist Control Module																																																									
4	2016	Escalade	Body	Frontview Camera Module																																																									
4	2016	Escalade	Body	Steering Column Lock Control Module																																																									
4	2016	Escalade	Body	Long Range Radar Sensor Module		V																																																							
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																									
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																									
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																									
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																									
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																										
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																																										
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2016	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2016	Escalade ESV	Body	Body Control Module																																																										
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2016	Escalade ESV	Body	Passenger Presence Module																																																										
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left				V	V																																																					
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right				V	V																																																					
4	2016	Escalade ESV	Body	Instrument Cluster																																																										
4	2016	Escalade ESV	Body	Radio Control																																																										
4	2016	Escalade ESV	Body	HVAC Control																																																										
4	2016	Escalade ESV	Body	Active Safety Control Module	V																																																									
4	2016	Escalade ESV	Body	Video Processing Control Module								V	V	V	V	V																																														
4	2016	Escalade ESV	Body	Radio																																																										
4	2016	Escalade ESV	Body	Amplifier																																																										
4	2016	Escalade ESV	Body	Media Disc Player																																																										
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																										
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																										
4	2016	Escalade ESV	Body	HVAC Control Module																																																										
4	2016	Escalade ESV	Body	Liftgate Control Module																																																										
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																										
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																										
4	2016	Escalade ESV	Body	Assist Step Control Module																																																										
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
4	2016	Escalade ESV	Body	Parking Assist Control Module																																																										
4	2016	Escalade ESV	Body	Frontview Camera Module																																																										
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																										
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module		V																																																								
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module													V	V	V																																											
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V																																	
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module													V	V	V																																											
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V																																	
ALL	2004	Hearse	Chassis	DRP/ABS/TCS																																																										
ALL	2004	Hearse	Chassis	Magna Steer																																																										
ALL	2004	Hearse	Chassis	Rear Integration Module																																																										
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																										
ALL	2004	Hearse	Body	Amplifier (Delco)																																					V	V	V																			
ALL	2004	Hearse	Body	Dash Integration Module																																					V	V	V							V	V											
ALL	2004	Hearse	Body	Driver Door Switch																																					V	V																				
ALL	2004	Hearse	Body	Driver Door Module																																					V	V	V							V												
ALL	2004	Hearse	Body	Passenger Door Module																																					V	V	V							V												
ALL	2004	Hearse	Body	Instrument Panel Cluster																																					V	V								V		V										
ALL	2004	Hearse	Body	Instrument Panel Module																																									V			V	V	V		V										
ALL	2004	Hearse	Body	Personalization																																															V											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
ALL	2004	Hearse	Body	Radio																																														V		V							V
ALL	2004	Hearse	Body	Rear Integration Module																																					V	V	V																
ALL	2004	Hearse	Body	Remote Function Actuation																																															V							
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																																					V	V																	
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																					V	V								V		V							
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module													V	V	V																																							
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V																														
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module													V	V	V																																							
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V																														
ALL	2004	Limousine	Chassis	DRP/ABS/TCS																																																							
ALL	2004	Limousine	Chassis	Magna Steer																																																							
ALL	2004	Limousine	Chassis	Rear Integration Module																																																							
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																							
ALL	2004	Limousine	Body	Amplifier (Delco)																																					V	V	V																	
ALL	2004	Limousine	Body	Dash Integration Module																																					V	V	V							V	V									
ALL	2004	Limousine	Body	Driver Door Switch																																					V	V																	
ALL	2004	Limousine	Body	Driver Door Module																																					V	V	V							V										
ALL	2004	Limousine	Body	Passenger Door Module																																					V	V	V							V										
ALL	2004	Limousine	Body	Left Mid Door Module																																					V	V	V																	
ALL	2004	Limousine	Body	Left Rear Door Module																																					V	V	V																	
ALL	2004	Limousine	Body	Right Mid Door Module																																					V	V	V																	
ALL	2004	Limousine	Body	Right Rear Door Module																																					V	V	V																	
ALL	2004	Limousine	Body	Instrument Panel Cluster																																					V	V								V		V							
ALL	2004	Limousine	Body	Instrument Panel Module																																								V			V	V		V		V							
ALL	2004	Limousine	Body	Memory Seat Module																																																							
ALL	2004	Limousine	Body	Navigation Radio																																																							V
ALL	2004	Limousine	Body	Personalization																																														V								
ALL	2004	Limousine	Body	Radio																																														V		V							V
ALL	2004	Limousine	Body	Rear Climate Control Panel																																							V			V					V								
ALL	2004	Limousine	Body	Rear Integration Module																																					V	V	V																	
ALL	2004	Limousine	Body	Remote Function Actuation																																															V								
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																																					V	V																	
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																					V	V								V		V							
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module													V	V	V																																							
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V																														
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module													V	V	V																																							
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V																														
ALL	2005	Hearse	Chassis	DRP/ABS/TCS																																																						
ALL	2005	Hearse	Chassis	Magna Steer																																																						
ALL	2005	Hearse	Chassis	Rear Integration Module																																																						
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																						
ALL	2005	Hearse	Body	Amplifier (Delco)																																					V	V	V																	
ALL	2005	Hearse	Body	Dash Integration Module																																					V	V	V							V	V									
ALL	2005	Hearse	Body	Driver Door Switch																																					V	V																	
ALL	2005	Hearse	Body	Driver Door Module																																					V	V	V							V										
ALL	2005	Hearse	Body	Passenger Door Module																																					V	V	V							V										
ALL	2005	Hearse	Body	Instrument Panel Cluster																																					V	V								V		V							
ALL	2005	Hearse	Body	Instrument Panel Module																																								V			V	V		V		V							
ALL	2005	Hearse	Body	Personalization																																														V								
ALL	2005	Hearse	Body	Radio																																														V		V							V
ALL	2005	Hearse	Body	Rear Integration Module																																					V	V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
ALL	2005	Hearse	Body	Remote Function Actuation																																																								
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																					V																			V
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																					V	V									V								
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module													V	V	V																																								
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																V	V	V		V	V	V	V		V																														
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module													V	V	V																																								
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																V	V	V		V	V	V	V		V																														
ALL	2005	Limousine	Chassis	DRP/ABS/TCS																																																								
ALL	2005	Limousine	Chassis	Magna Steer																																																								
ALL	2005	Limousine	Chassis	Rear Integration Module																																																								
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																								
ALL	2005	Limousine	Body	Amplifier (Delco)																																					V	V	V																		
ALL	2005	Limousine	Body	Dash Integration Module																																					V	V	V							V	V									
ALL	2005	Limousine	Body	Driver Door Switch																																					V	V																		
ALL	2005	Limousine	Body	Driver Door Module																																					V	V	V							V										
ALL	2005	Limousine	Body	Passenger Door Module																																					V	V	V							V										
ALL	2005	Limousine	Body	Left Mid Door Module																																					V	V	V																		
ALL	2005	Limousine	Body	Left Rear Door Module																																					V	V	V																		
ALL	2005	Limousine	Body	Right Mid Door Module																																					V	V	V																		
ALL	2005	Limousine	Body	Right Rear Door Module																																					V	V	V																		
ALL	2005	Limousine	Body	Instrument Panel Cluster																																					V	V								V		V							
ALL	2005	Limousine	Body	Instrument Panel Module																																								V			V	V		V		V							
ALL	2005	Limousine	Body	Memory Seat Module																																																								
ALL	2005	Limousine	Body	Navigation Radio																																																							V
ALL	2005	Limousine	Body	Personalization																																													V										
ALL	2005	Limousine	Body	Radio																																													V		V							V
ALL	2005	Limousine	Body	Rear Climate Control Panel																																							V			V					V								
ALL	2005	Limousine	Body	Rear Integration Module																																					V	V	V																		
ALL	2005	Limousine	Body	Remote Function Actuation																																																								
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint																																					V	V																		
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																					V	V									V								
ALL	2006	Hearse	Powertrain	Engine Control Module																																																								
ALL	2006	Hearse	Powertrain	Transmission Control Module																V	V	V		V	V	V	V										V	V																							
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																																								
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																								
ALL	2006	Hearse	Body	Amplifier (Bose)																																																								
ALL	2006	Hearse	Body	Body Control Module			V																																			V	V																	
ALL	2006	Hearse	Body	Digital Radio Receiver																																																								
ALL	2006	Hearse	Body	Driver Door Switch																																					V	V	V																		
ALL	2006	Hearse	Body	Driver Position Module																																																								
ALL	2006	Hearse	Body	HVAC Control Module																																								V				V												
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																								
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																								
ALL	2006	Hearse	Body	Passenger Door Switch																																					V	V	V																		
ALL	2006	Hearse	Body	Passenger Presence System																																					V																			
ALL	2006	Hearse	Body	Radio																																																								
ALL	2006	Hearse	Body	Rear Heated Seat Module																																																								
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																								
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																					V																			
ALL	2006	Hearse	Body	Theft Deterrent Module																																																								
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
ALL	2006	Limousine	Powertrain	Engine Control Module																																																								
ALL	2006	Limousine	Powertrain	Transmission Control Module																V	V	V		V	V	V	V										V	V																					
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																																							
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																							
ALL	2006	Limousine	Body	Amplifier (Bose)																																																							
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																							
ALL	2006	Limousine	Body	Body Control Module			V																																			V	V																	
ALL	2006	Limousine	Body	Digital Radio Receiver																																																							
ALL	2006	Limousine	Body	Driver Door Switch																																					V	V	V																	
ALL	2006	Limousine	Body	Driver Position Module																																																							
ALL	2006	Limousine	Body	HVAC Control Module																																								V				V											
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																							
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																							
ALL	2006	Limousine	Body	Passenger Door Switch																																					V	V	V																	
ALL	2006	Limousine	Body	Passenger Presence System																																					V																	
ALL	2006	Limousine	Body	Radio																																																							
ALL	2006	Limousine	Body	Rear Heated Seat Module																																																							
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																							
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																					V																	
ALL	2006	Limousine	Body	Theft Deterrent Module																																																							
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																																							
ALL	2007	Hearse	Powertrain	Engine Control Module																											V		V	V																										
ALL	2007	Hearse	Powertrain	Transmission Control Module																V	V	V		V	V	V	V										V	V																					
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																							
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																			V																					
ALL	2007	Hearse	Body	Amplifier (Bose)																																																							
ALL	2007	Hearse	Body	Body Control Module			V																																			V	V																	
ALL	2007	Hearse	Body	Digital Radio Receiver																																																							
ALL	2007	Hearse	Body	Driver Door Switch																																					V	V	V																	
ALL	2007	Hearse	Body	Driver Position Module																																																							
ALL	2007	Hearse	Body	HVAC Control Module																																								V				V											
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																							
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																							
ALL	2007	Hearse	Body	Passenger Door Switch																																					V	V	V																	
ALL	2007	Hearse	Body	Passenger Presence System																																					V																	
ALL	2007	Hearse	Body	Radio																																																							
ALL	2007	Hearse	Body	Rear Heated Seat Module																																																							
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																					V																	
ALL	2007	Hearse	Body	Theft Deterrent Module																																																							
ALL	2007	Limousine	Powertrain	Engine Control Module																											V		V	V																										
ALL	2007	Limousine	Powertrain	Transmission Control Module																V	V	V		V	V	V	V										V	V																					
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																							
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																			V																					
ALL	2007	Limousine	Body	Amplifier (Bose)																																																							
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																																							
ALL	2007	Limousine	Body	Body Control Module			V																																			V	V																	
ALL	2007	Limousine	Body	Digital Radio Receiver																																																							
ALL	2007	Limousine	Body	Driver Door Switch																																					V	V	V																	
ALL	2007	Limousine	Body	Driver Position Module																																																							
ALL	2007	Limousine	Body	HVAC Control Module																																								V				V											
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																							
ALL	2007	Limousine	Body	Passenger Door Switch																																				V	V	V																	
ALL	2007	Limousine	Body	Passenger Presence System																																				V																			
ALL	2007	Limousine	Body	Radio																																																						
ALL	2007	Limousine	Body	Rear Heated Seat Module																																																						
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																				V																		
ALL	2007	Limousine	Body	Theft Deterrent Module																																																						
ALL	2008	Hearse	Powertrain	Engine Control Module																											V		V	V																									
ALL	2008	Hearse	Powertrain	Transmission Control Module																V	V	V		V	V	V	V									V	V																					
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																						
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																			V																			
ALL	2008	Hearse	Body	Amplifier (Bose)																																																						
ALL	2008	Hearse	Body	Body Control Module			V																																			V	V																
ALL	2008	Hearse	Body	Climate Control Seat Module																																																						
ALL	2008	Hearse	Body	Digital Radio Receiver																																																						
ALL	2008	Hearse	Body	Driver Door Switch																																				V	V	V																	
ALL	2008	Hearse	Body	Driver Position Module																																																						
ALL	2008	Hearse	Body	HVAC Control Module																																							V			V													
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																						
ALL	2008	Hearse	Body	Passenger Door Switch																																				V	V	V																	
ALL	2008	Hearse	Body	Passenger Presence System																																				V																		
ALL	2008	Hearse	Body	Radio																																																						
ALL	2008	Hearse	Body	Rear Heated Seat Module																																																						
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																				V																		
ALL	2008	Hearse	Body	Theft Deterrent Module																																																						
ALL	2008	Limousine	Powertrain	Engine Control Module																											V		V	V																									
ALL	2008	Limousine	Powertrain	Transmission Control Module																V	V	V		V	V	V	V									V	V																					
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																						
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																				V																		
ALL	2008	Limousine	Body	Amplifier (Bose)																																																						
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																						
ALL	2008	Limousine	Body	Body Control Module			V																																			V	V																
ALL	2008	Limousine	Body	Climate Control Seat Module																																																						
ALL	2008	Limousine	Body	Digital Radio Receiver																																																						
ALL	2008	Limousine	Body	Driver Door Switch																																				V	V	V																	
ALL	2008	Limousine	Body	Driver Position Module																																																						
ALL	2008	Limousine	Body	HVAC Control Module																																							V			V													
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																						
ALL	2008	Limousine	Body	Passenger Door Switch																																				V	V	V																	
ALL	2008	Limousine	Body	Passenger Presence System																																				V																		
ALL	2008	Limousine	Body	Radio																																																						
ALL	2008	Limousine	Body	Rear Heated Seat Module																																																						
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																				V																		
ALL	2008	Limousine	Body	Theft Deterrent Module																																																						
ALL	2009	Hearse	Powertrain	Engine Control Module																											V		V	V																									
ALL	2009	Hearse	Powertrain	Transmission Control Module																V	V	V		V	V	V	V									V	V																					
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																						
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																				V																		
ALL	2009	Hearse	Body	Amplifier (Bose)																																																						
ALL	2009	Hearse	Body	Body Control Module			V																																			V	V																
ALL	2009	Hearse	Body	Climate Control Seat Module																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
ALL	2009	Hearse	Body	Digital Radio Receiver																																																								
ALL	2009	Hearse	Body	Driver Door Switch																																				V	V	V																		
ALL	2009	Hearse	Body	Driver Position Module																																																								
ALL	2009	Hearse	Body	HVAC Control Module																																							V				V													
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																								
ALL	2009	Hearse	Body	Passenger Door Switch																																				V	V	V																		
ALL	2009	Hearse	Body	Passenger Presence System																																				V																			
ALL	2009	Hearse	Body	Radio																																																								
ALL	2009	Hearse	Body	Rear Heated Seat Module																																																								
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																				V																			
ALL	2009	Hearse	Body	Theft Deterrent Module																																																								
ALL	2009	Limousine	Powertrain	Engine Control Module																											V		V	V																											
ALL	2009	Limousine	Powertrain	Transmission Control Module																V	V	V		V	V	V	V									V	V																						
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																								
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																			V																					
ALL	2009	Limousine	Body	Amplifier (Bose)																																																								
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																								
ALL	2009	Limousine	Body	Body Control Module			V																																			V	V																	
ALL	2009	Limousine	Body	Climate Control Seat Module																																																								
ALL	2009	Limousine	Body	Digital Radio Receiver																																																								
ALL	2009	Limousine	Body	Driver Door Switch																																				V	V	V																		
ALL	2009	Limousine	Body	Driver Position Module																																																								
ALL	2009	Limousine	Body	HVAC Control Module																																							V				V													
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																								
ALL	2009	Limousine	Body	Passenger Door Switch																																				V	V	V																		
ALL	2009	Limousine	Body	Passenger Presence System																																				V																			
ALL	2009	Limousine	Body	Radio																																																								
ALL	2009	Limousine	Body	Rear Heated Seat Module																																																								
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																				V																			
ALL	2009	Limousine	Body	Theft Deterrent Module																																																								
ALL	2010	Hearse	Powertrain	Engine Control Module																											V		V	V																											
ALL	2010	Hearse	Powertrain	Transmission Control Module																V	V	V		V	V	V	V									V	V																						
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																								
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																			V																					
ALL	2010	Hearse	Body	Amplifier (Bose)																																																								
ALL	2010	Hearse	Body	Body Control Module			V																																			V	V																	
ALL	2010	Hearse	Body	Climate Control Seat Module																																																								
ALL	2010	Hearse	Body	Digital Radio Receiver																																																								
ALL	2010	Hearse	Body	Driver Door Switch																																				V	V	V																		
ALL	2010	Hearse	Body	Driver Position Module																																																								
ALL	2010	Hearse	Body	HVAC Control Module																																							V				V													
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																								
ALL	2010	Hearse	Body	Passenger Door Switch																																				V	V	V																		
ALL	2010	Hearse	Body	Passenger Presence System																																				V																			
ALL	2010	Hearse	Body	Radio																																																								
ALL	2010	Hearse	Body	Rear Heated Seat Module																																																								
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																				V																			
ALL	2010	Hearse	Body	Theft Deterrent Module																																																								
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																																								
ALL	2010	Limousine	Powertrain	Engine Control Module																											V		V	V																											
ALL	2010	Limousine	Powertrain	Transmission Control Module																V	V	V		V	V	V	V									V	V																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																									
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																			V																						
ALL	2010	Limousine	Body	Amplifier (Bose)																																																									
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																									
ALL	2010	Limousine	Body	Body Control Module			V																																			V	V																		
ALL	2010	Limousine	Body	Climate Control Seat Module																																																									
ALL	2010	Limousine	Body	Digital Radio Receiver																																																									
ALL	2010	Limousine	Body	Driver Door Switch																																					V	V	V																		
ALL	2010	Limousine	Body	Driver Position Module																																																									
ALL	2010	Limousine	Body	HVAC Control Module																																								V			V														
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2010	Limousine	Body	Passenger Door Switch																																					V	V	V																		
ALL	2010	Limousine	Body	Passenger Presence System																																					V																			
ALL	2010	Limousine	Body	Radio																																																									
ALL	2010	Limousine	Body	Rear Heated Seat Module																																																									
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																					V																			
ALL	2010	Limousine	Body	Theft Deterrent Module																																																									
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																																									
ALL	2011	Hearse	Powertrain	Engine Control Module																											V		V	V																											
ALL	2011	Hearse	Powertrain	Transmission Control Module																																V	V																								
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																									
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																			V																						
ALL	2011	Hearse	Body	Amplifier (Bose)																																																									
ALL	2011	Hearse	Body	Body Control Module			V																																			V	V																		
ALL	2011	Hearse	Body	Climate Control Seat Module																																																									
ALL	2011	Hearse	Body	Digital Radio Receiver																																																									
ALL	2011	Hearse	Body	Driver Door Switch																																					V	V	V																		
ALL	2011	Hearse	Body	Driver Position Module																																																									
ALL	2011	Hearse	Body	HVAC Control Module																																								V			V														
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																									
ALL	2011	Hearse	Body	Passenger Door Switch																																					V	V	V																		
ALL	2011	Hearse	Body	Passenger Presence System																																					V																			
ALL	2011	Hearse	Body	Radio																																																									
ALL	2011	Hearse	Body	Rear Heated Seat Module																																																									
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																					V																			
ALL	2011	Hearse	Body	Theft Deterrent Module																																																									
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																																									
ALL	2011	Limousine	Powertrain	Engine Control Module																											V		V	V																											
ALL	2011	Limousine	Powertrain	Transmission Control Module																																V	V																								
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																									
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																			V																						
ALL	2011	Limousine	Body	Amplifier (Bose)																																																									
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2011	Limousine	Body	Body Control Module			V																																			V	V																		
ALL	2011	Limousine	Body	Climate Control Seat Module																																																									
ALL	2011	Limousine	Body	Digital Radio Receiver																																																									
ALL	2011	Limousine	Body	Driver Door Switch																																					V	V	V																		
ALL	2011	Limousine	Body	Driver Position Module																																																									
ALL	2011	Limousine	Body	HVAC Control Module																																								V			V														
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2011	Limousine	Body	Passenger Door Switch																																					V	V	V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
ALL	2011	Limousine	Body	Passenger Presence System																																					V																					
ALL	2011	Limousine	Body	Radio																																																										
ALL	2011	Limousine	Body	Rear Heated Seat Module																																																											
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																					V																						
ALL	2011	Limousine	Body	Theft Deterrent Module																																																										
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module			V	V	V																																																				
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																			V																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto																			V																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2004	ALL	Body	Heating and Air Conditioning Manual																			V																																								
C	2004	ALL	Body	Instrument Panel Cluster																																																											
C	2004	ALL	Body	OnStar																																																V	V								
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Base Radio																																																										
C	2004	ALL	Body	Uplevel Radio																																																										
C	2004	ALL	Body	Navigation Radio								V																																																		
C	2004	ALL	Body	Rear Aux. Climate Module																																																											
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																										
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module			V	V	V																																																					
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	ESC																																																									
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2005	ALL	Chassis	VSES																																																									
C	2005	ALL	Body	Amplifier (Bose)																																																										
C	2005	ALL	Body	Body Control Module																																																										
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																																										
C	2005	ALL	Body	Driver Seat Module																			V																																								
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																			V																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2005	ALL	Body	Heating and Air Conditioning Manual																			V																																							
C	2005	ALL	Body	Instrument Panel Cluster																																																										
C	2005	ALL	Body	Passenger Door Module																																																										
C	2005	ALL	Body	Passenger Presence System																																																										
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio								V																																																		
C	2005	ALL	Body	Rear Aux. Climate Module																																																											
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																																										
C	2005	ALL	Body	Remote Function Actuation																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																V	V								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module			V	V	V																																																					
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																									
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																			V																																								
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																			V																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																			V																																								
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio								V																																																		
C	2006	ALL	Body	Rear Aux. Climate Module																																																											
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																										
C	2006	ALL	Body	Supplemental Inflatable Restraint	V																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																V	V	V							
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																					
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	ALL	Chassis	Electronic Brake Control Module													V																																													
C	2007	ALL	Chassis	Electronic Suspension Control																																																											
C	2007	ALL	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2007	ALL	Body	Assist Step Controller																																																										
C	2007	ALL	Body	Body Control Module			V																													V																										
C	2007	ALL	Body	Body Control Module (aux.)																																																										
C	2007	ALL	Body	Digital Radio Receiver																																																										
C	2007	ALL	Body	Driver Door Switch																																																										
C	2007	ALL	Body	HVAC Control Module																																																										
C	2007	ALL	Body	Inside Rear View Mirror Module																																																										
C	2007	ALL	Body	Instrument Panel Cluster																																																										
C	2007	ALL	Body	Lift Gate Module																																																										
C	2007	ALL	Body	Memory Seat Module																					V	V																																				
C	2007	ALL	Body	Park Assist Module																																																										
C	2007	ALL	Body	Passenger Door Switch																																																										
C	2007	ALL	Body	Passenger Presence System																																																										
C	2007	ALL	Body	Radio																																																										
C	2007	ALL	Body	Rear Heated Seat Module																																																										
C	2007	ALL	Body	Rear HVAC/RSA																																																										
C	2007	ALL	Body	Rollover Sensor																																																										
C	2007	ALL	Body	Supplemental Inflatable Restraint																			V																																							
C	2007	ALL	Body	Theft Deterrent Module		V																																																								
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																					
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	ALL	Chassis	Electronic Brake Control Module													V																																													
C	2008	ALL	Chassis	Electronic Suspension Control																																																										
C	2008	ALL	Chassis	Trailer Brake Control Module																																																										
C	2008	ALL	Body	Amplifier (Bose)																																																										
C	2008	ALL	Body	Assist Step Controller																																																										
C	2008	ALL	Body	Body Control Module			V																													V																										
C	2008	ALL	Body	Body Control Module (aux.)																																																										
C	2008	ALL	Body	Digital Radio Receiver																																																										
C	2008	ALL	Body	Driver Door Switch																																																										
C	2008	ALL	Body	HVAC Control Module																																																										
C	2008	ALL	Body	Inside Rear View Mirror Module																																																										
C	2008	ALL	Body	Instrument Panel Cluster																																																										
C	2008	ALL	Body	Lift Gate Module																																																										
C	2008	ALL	Body	Memory Seat Module																					V	V																																				
C	2008	ALL	Body	Park Assist Module																																																										
C	2008	ALL	Body	Passenger Door Switch																																																										
C	2008	ALL	Body	Passenger Presence System																																																										
C	2008	ALL	Body	Radio																																																										
C	2008	ALL	Body	Rear Heated Seat Module																																																										
C	2008	ALL	Body	Rear HVAC/RSA																																																										
C	2008	ALL	Body	Rollover Sensor																																																										
C	2008	ALL	Body	Supplemental Inflatable Restraint																			V																																							
C	2008	ALL	Body	Theft Deterrent Module		V																																																								
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																					
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	ALL	Chassis	Electronic Brake Control Module													V																																													
C	2009	ALL	Chassis	Electronic Suspension Control																																																										
C	2009	ALL	Chassis	Trailer Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2009	ALL	Body	Amplifier (Bose)																																																										
C	2009	ALL	Body	Assist Step Controller																																																										
C	2009	ALL	Body	Body Control Module			V																													V																										
C	2009	ALL	Body	Body Control Module (aux.)																																																										
C	2009	ALL	Body	Digital Radio Receiver																																																										
C	2009	ALL	Body	Driver Door Switch																																																										
C	2009	ALL	Body	HVAC Control Module																																																										
C	2009	ALL	Body	Inside Rear View Mirror Module																																																										
C	2009	ALL	Body	Instrument Panel Cluster																																																										
C	2009	ALL	Body	Left Side Object Detection Module																																																										
C	2009	ALL	Body	Lift Gate Module																																																										
C	2009	ALL	Body	Memory Seat Module																					V	V																																					
C	2009	ALL	Body	Park Assist Module																																																										
C	2009	ALL	Body	Passenger Door Switch																																																										
C	2009	ALL	Body	Passenger Presence System																																																										
C	2009	ALL	Body	Radio																																																										
C	2009	ALL	Body	Rear Heated Seat Module																																																										
C	2009	ALL	Body	Rear HVAC/RSA																																																										
C	2009	ALL	Body	Right Side Object Detection Module																																																										
C	2009	ALL	Body	Rollover Sensor																																																										
C	2009	ALL	Body	Supplemental Inflatable Restraint																			V																																							
C	2009	ALL	Body	Theft Deterrent Module		V																																																								
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																V				
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																															V				
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	ALL	Chassis	Electronic Brake Control Module													V																																													
C	2010	ALL	Chassis	Electronic Suspension Control																																																											
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	ALL	Body	Amplifier (Bose)																																																										
C	2010	ALL	Body	Assist Step Controller																																																										
C	2010	ALL	Body	Body Control Module			V																													V																										
C	2010	ALL	Body	Body Control Module (aux.)																																																										
C	2010	ALL	Body	Digital Radio Receiver																																																										
C	2010	ALL	Body	Driver Door Switch																																																										
C	2010	ALL	Body	HVAC Control Module																																																										
C	2010	ALL	Body	Inside Rear View Mirror Module																																																										
C	2010	ALL	Body	Instrument Panel Cluster																																																										
C	2010	ALL	Body	Left Side Object Detection Module																																																										
C	2010	ALL	Body	Lift Gate Module																																																										
C	2010	ALL	Body	Memory Seat Module																					V	V																																					
C	2010	ALL	Body	Park Assist Module																																																										
C	2010	ALL	Body	Passenger Door Switch																																																										
C	2010	ALL	Body	Passenger Presence System																																																										
C	2010	ALL	Body	Radio																																																										
C	2010	ALL	Body	Rear Heated Seat Module																																																										
C	2010	ALL	Body	Rear HVAC/RSA																																																										
C	2010	ALL	Body	Right Side Object Detection Module																																																										
C	2010	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2010	ALL	Body	Theft Deterrent Module		V																																																							
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																									
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V	V																																																			
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																									
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																																									
E	2004	ALL	Chassis	Electronic Suspension Control																																																									
E	2004	ALL	Chassis	Tire Pressure Monitor																																																									
E	2004	ALL	Chassis	VES																																																									
E	2004	ALL	Body	Amplifier (Bose)																																																									
E	2004	ALL	Body	Amplifier (Delco)																																																									
E	2004	ALL	Body	Climate Control Panel																																																									
E	2004	ALL	Body	Dash Integration Module																																																									
E	2004	ALL	Body	Disc Player and Video Display																																																									
E	2004	ALL	Body	Driver Door Switch																																																									
E	2004	ALL	Body	Driver Door Module																																																									
E	2004	ALL	Body	Passenger Door Module																																																									
E	2004	ALL	Body	Left Rear Door Module																																																									
E	2004	ALL	Body	Right Rear Door Module																																																									
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																									
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																									
E	2004	ALL	Body	Instrument Panel Cluster																																																									
E	2004	ALL	Body	Memory Seat Module																																																									
E	2004	ALL	Body	OnStar																																																V	V								
E	2004	ALL	Body	Personalization																																																									
E	2004	ALL	Body	Base Radio							V	V																																																	
E	2004	ALL	Body	Navigation Radio							V																																																		
E	2004	ALL	Body	Rear Integration Module																																																									
E	2004	ALL	Body	Rear Seat Module																																																									
E	2004	ALL	Body	Remote Function Actuation																																																									
E	2004	ALL	Body	Supplemental Inflatable Restraint	V																																																									
E	2004	ALL	Body	TV Antenna Module																																																									
E	2004	ALL	Body	Vehicle Theft Deterrent		V																																																								
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V	V																																																			
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V	V																																																			
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																									
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																																									
E	2005	ALL	Chassis	Electronic Suspension Control																																																									
E	2005	ALL	Chassis	Tire Pressure Monitor																																																									
E	2005	ALL	Chassis	VES																																																									
E	2005	ALL	Body	Amplifier (Bose)																																																									
E	2005	ALL	Body	Amplifier (Delco)																																																									
E	2005	ALL	Body	Climate Control Panel																																																									
E	2005	ALL	Body	Dash Integration Module																																																									
E	2005	ALL	Body	Disc Player and Video Display																																																									
E	2005	ALL	Body	Driver Door Switch																																																									
E	2005	ALL	Body	Driver Door Module																																																									
E	2005	ALL	Body	Passenger Door Module																																																									
E	2005	ALL	Body	Left Rear Door Module																																																									
E	2005	ALL	Body	Right Rear Door Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2005	ALL	Body	Instrument Panel Cluster																																																										
E	2005	ALL	Body	Memory Seat Module																																																										
E	2005	ALL	Body	Personalization																																																										
E	2005	ALL	Body	Base Radio							V	V																																																		
E	2005	ALL	Body	Navigation Radio							V																																																			
E	2005	ALL	Body	Rear Integration Module																																																										
E	2005	ALL	Body	Rear Seat Module																																																										
E	2005	ALL	Body	Remote Function Actuation																																																										
E	2005	ALL	Body	Supplemental Inflatable Restraint	V																																																										
E	2005	ALL	Body	TV Antenna Module																																																										
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																V	V								
E	2005	ALL	Body	Vehicle Theft Deterrent		V																																																								
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V	V																																																				
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V	V																																																				
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																										
E	2006	ALL	Chassis	Electronic Suspension Control																																																										
E	2006	ALL	Chassis	Tire Pressure Monitor																																																										
E	2006	ALL	Chassis	VES																																																										
E	2006	ALL	Body	Amplifier (Bose)																																																										
E	2006	ALL	Body	Amplifier (Delco)																																																										
E	2006	ALL	Body	Climate Control Panel																																																										
E	2006	ALL	Body	Dash Integration Module																																																										
E	2006	ALL	Body	Disc Player and Video Display																																																										
E	2006	ALL	Body	Driver Door Switch																																																										
E	2006	ALL	Body	Driver Door Module																																																										
E	2006	ALL	Body	Passenger Door Module																																																										
E	2006	ALL	Body	Left Rear Door Module																																																										
E	2006	ALL	Body	Right Rear Door Module																																																										
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2006	ALL	Body	Instrument Panel Cluster																																																										
E	2006	ALL	Body	Lift Gate Module																																																										
E	2006	ALL	Body	Memory Seat Module																																																										
E	2006	ALL	Body	Personalization																																																										
E	2006	ALL	Body	Base Radio							V	V																																																		
E	2006	ALL	Body	Navigation Radio							V																																																			
E	2006	ALL	Body	Rear Integration Module																																																										
E	2006	ALL	Body	Rear Seat Module																																																										
E	2006	ALL	Body	Remote Function Actuation																																																										
E	2006	ALL	Body	Supplemental Inflatable Restraint	V																																																										
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																V	V	V							
E	2006	ALL	Body	Vehicle Theft Deterrent		V																																																								
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																															V			V
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V																																														V			V
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2007	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
E	2007	ALL	Chassis	Electronic Suspension Control																																																										
E	2007	ALL	Body	Amplifier (Bose)																																																										
E	2007	ALL	Body	Body Control Module			V																		V												V																									
E	2007	ALL	Body	Body Control Module (aux.)																																																										
E	2007	ALL	Body	Digital Radio Receiver																																																										
E	2007	ALL	Body	Driver Door Switch																																																										
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2007	ALL	Body	HVAC Control Module																																																										
E	2007	ALL	Body	Instrument Panel Cluster																																																										
E	2007	ALL	Body	Lift Gate Module																																																										
E	2007	ALL	Body	Memory Seat Module																					V	V																																				
E	2007	ALL	Body	Park Assist Module																																																										
E	2007	ALL	Body	Passenger Door Switch																																																										
E	2007	ALL	Body	Passenger Presence System																																																										
E	2007	ALL	Body	Radio																																																										
E	2007	ALL	Body	Rear HVAC/RSA																																																										
E	2007	ALL	Body	Rear Seat Module																																																										
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																										
E	2007	ALL	Body	Rollover Sensor																																																										
E	2007	ALL	Body	Supplemental Inflatable Restraint																			V																																							
E	2007	ALL	Body	Theft Deterrent Module		V																																																								
E	2007	ALL	Body	TV Antenna Module																																																										
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																																V			V		
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V																																																V			V		
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2008	ALL	Chassis	Electronic Brake Control Module											V	V	V																																													
E	2008	ALL	Chassis	Electronic Suspension Control																																																										
E	2008	ALL	Body	Amplifier (Bose)																																																										
E	2008	ALL	Body	Body Control Module			V																			V																																				
E	2008	ALL	Body	Body Control Module (aux.)																																																										
E	2008	ALL	Body	Digital Radio Receiver																																																										
E	2008	ALL	Body	Driver Door Switch																																																										
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2008	ALL	Body	HVAC Control Module																																																										
E	2008	ALL	Body	Instrument Panel Cluster																																																										
E	2008	ALL	Body	Lift Gate Module																																																										
E	2008	ALL	Body	Memory Seat Module																					V	V																																				
E	2008	ALL	Body	Park Assist Module																																																										
E	2008	ALL	Body	Passenger Door Switch																																																										
E	2008	ALL	Body	Passenger Presence System																																																										
E	2008	ALL	Body	Radio																																																										
E	2008	ALL	Body	Rear HVAC/RSA																																																										
E	2008	ALL	Body	Rear Seat Module																																																										
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
E	2008	ALL	Body	Rollover Sensor																																																										
E	2008	ALL	Body	Supplemental Inflatable Restraint																			V																																							
E	2008	ALL	Body	Theft Deterrent Module		V																																																								
E	2008	ALL	Body	TV Antenna Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																																V			V
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																							
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module					V																																															V			V
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																							
E	2009	ALL	Chassis	Electronic Brake Control Module											V	V	V																																										
E	2009	ALL	Chassis	Electronic Suspension Control																																																							
E	2009	ALL	Body	Amplifier (Bose)																																																						
E	2009	ALL	Body	Body Control Module			V																													V																							
E	2009	ALL	Body	Body Control Module (aux.)																																																						
E	2009	ALL	Body	Digital Radio Receiver																																																						
E	2009	ALL	Body	Driver Door Switch																																																						
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																						
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																						
E	2009	ALL	Body	HVAC Control Module																																																						
E	2009	ALL	Body	Instrument Panel Cluster																																																						
E	2009	ALL	Body	Lift Gate Module																																																						
E	2009	ALL	Body	Memory Seat Module																					V	V																																		
E	2009	ALL	Body	Park Assist Module																																																						
E	2009	ALL	Body	Passenger Door Switch																																																						
E	2009	ALL	Body	Passenger Presence System																																																						
E	2009	ALL	Body	Radio																																																						
E	2009	ALL	Body	Rear HVAC/RSA																																																						
E	2009	ALL	Body	Rear Seat Module																																																						
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																						
E	2009	ALL	Body	Rollover Sensor																																																						
E	2009	ALL	Body	Supplemental Inflatable Restraint																			V																																				
E	2009	ALL	Body	Theft Deterrent Module		V																																																					
E	2009	ALL	Body	TV Antenna Module																																																						
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module			V	V	V																																																		
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																							
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																							
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																						
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																						
K	2004	ALL	Chassis	ESC																																																						
K	2004	ALL	Chassis	Rear Wheel Steering																																																						
K	2004	ALL	Chassis	Tire Pressure Monitor																																																						
K	2004	ALL	Chassis	VSES																																																						
K	2004	ALL	Body	Amplifier (Bose)																																																						
K	2004	ALL	Body	Body Control Module																																																						
K	2004	ALL	Body	CD Changer																																																						
K	2004	ALL	Body	Chime																																																						
K	2004	ALL	Body	Driver Door Module																																																						
K	2004	ALL	Body	Driver Seat Module																			V																																				
K	2004	ALL	Body	Heating and Air Conditioning Auto																			V																																				
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																						
K	2004	ALL	Body	Heating and Air Conditioning Manual																			V																																				
K	2004	ALL	Body	Instrument Panel Cluster																																																						
K	2004	ALL	Body	OnStar																																																V	V						
K	2004	ALL	Body	Passenger Door Module																																																						
K	2004	ALL	Body	Passenger Presence System																																																						
K	2004	ALL	Body	Base Radio																																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2004	ALL	Body	Uplevel Radio																																																										
K	2004	ALL	Body	Navigation Radio								V																																																		
K	2004	ALL	Body	Rear Aux. Climate Module																																																										
K	2004	ALL	Body	Rear HVAC																																																										
K	2004	ALL	Body	Rear Seat Audio																																																										
K	2004	ALL	Body	Rear Seat Entertainment																																																										
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module			V	V	V																																																					
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																			V																																							
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																			V																																							
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																			V																																							
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio								V																																																		
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Remote Function Actuation																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																															V	V										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module			V	V	V																																																					
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2006	ALL	Chassis	ESC																																																										
K	2006	ALL	Chassis	Tire Pressure Monitor																																																										
K	2006	ALL	Chassis	VSES																																																										
K	2006	ALL	Body	Amplifier (Bose)																																																										
K	2006	ALL	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2006	ALL	Body	CD Changer																																																								
K	2006	ALL	Body	Chime																																																								
K	2006	ALL	Body	Disc Player and Video Display																																																								
K	2006	ALL	Body	Driver Door Module																																																								
K	2006	ALL	Body	Driver Seat Module																			V																																						
K	2006	ALL	Body	Generator Battery Control Module																																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto																			V																																						
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
K	2006	ALL	Body	Heating and Air Conditioning Manual																			V																																						
K	2006	ALL	Body	Instrument Panel Cluster																																																								
K	2006	ALL	Body	Passenger Door Module																																																								
K	2006	ALL	Body	Passenger Presence System																																																								
K	2006	ALL	Body	Base Radio																																																								
K	2006	ALL	Body	Uplevel Radio																																																								
K	2006	ALL	Body	Navigation Radio								V																																																
K	2006	ALL	Body	Rear Aux. Climate Module																																																								
K	2006	ALL	Body	Rear HVAC																																																								
K	2006	ALL	Body	Rear Seat Audio																																																								
K	2006	ALL	Body	Supplemental Inflatable Restraint	V																																																								
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																V	V	V						
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																			
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
K	2007	ALL	Chassis	Electronic Brake Control Module													V																																											
K	2007	ALL	Chassis	Electronic Suspension Control																																																								
K	2007	ALL	Body	Amplifier (Bose)																																																								
K	2007	ALL	Body	Assist Step Controller																																																								
K	2007	ALL	Body	Body Control Module			V																													V																									
K	2007	ALL	Body	Body Control Module (aux.)																																																								
K	2007	ALL	Body	Digital Radio Receiver																																																								
K	2007	ALL	Body	Driver Door Switch																																																								
K	2007	ALL	Body	HVAC Control Module																																																								
K	2007	ALL	Body	Inside Rear View Mirror Module																																																								
K	2007	ALL	Body	Instrument Panel Cluster																																																								
K	2007	ALL	Body	Lift Gate Module																																																								
K	2007	ALL	Body	Memory Seat Module																					V	V																																			
K	2007	ALL	Body	Park Assist Module																																																								
K	2007	ALL	Body	Passenger Door Switch																																																								
K	2007	ALL	Body	Passenger Presence System																																																								
K	2007	ALL	Body	Radio																																																								
K	2007	ALL	Body	Rear Heated Seat Module																																																								
K	2007	ALL	Body	Rear HVAC/RSA																																																								
K	2007	ALL	Body	Rollover Sensor																																																								
K	2007	ALL	Body	Supplemental Inflatable Restraint																			V																																						
K	2007	ALL	Body	Theft Deterrent Module		V																																																							
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																			
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
K	2008	ALL	Chassis	Electronic Brake Control Module													V																																											
K	2008	ALL	Chassis	Electronic Suspension Control																																																								
K	2008	ALL	Chassis	Trailer Brake Control Module																																																								
K	2008	ALL	Body	Amplifier (Bose)																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2008	ALL	Body	Assist Step Controller																																																										
K	2008	ALL	Body	Body Control Module			V																													V																										
K	2008	ALL	Body	Body Control Module (aux.)																																																										
K	2008	ALL	Body	Digital Radio Receiver																																																										
K	2008	ALL	Body	Driver Door Switch																																																										
K	2008	ALL	Body	HVAC Control Module																																																										
K	2008	ALL	Body	Inside Rear View Mirror Module																																																										
K	2008	ALL	Body	Instrument Panel Cluster																																																										
K	2008	ALL	Body	Lift Gate Module																																																										
K	2008	ALL	Body	Memory Seat Module																					V	V																																				
K	2008	ALL	Body	Park Assist Module																																																										
K	2008	ALL	Body	Passenger Door Switch																																																										
K	2008	ALL	Body	Passenger Presence System																																																										
K	2008	ALL	Body	Radio																																																										
K	2008	ALL	Body	Rear Heated Seat Module																																																										
K	2008	ALL	Body	Rear HVAC/RSA																																																										
K	2008	ALL	Body	Rollover Sensor																																																										
K	2008	ALL	Body	Supplemental Inflatable Restraint																			V																																							
K	2008	ALL	Body	Theft Deterrent Module		V																																																								
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																					
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	ALL	Chassis	Electronic Brake Control Module													V																																													
K	2009	ALL	Chassis	Electronic Suspension Control																																																										
K	2009	ALL	Chassis	Trailer Brake Control Module																																																										
K	2009	ALL	Body	Amplifier (Bose)																																																										
K	2009	ALL	Body	Assist Step Controller																																																										
K	2009	ALL	Body	Body Control Module			V																													V																										
K	2009	ALL	Body	Body Control Module (aux.)																																																										
K	2009	ALL	Body	Digital Radio Receiver																																																										
K	2009	ALL	Body	Driver Door Switch																																																										
K	2009	ALL	Body	HVAC Control Module																																																										
K	2009	ALL	Body	Inside Rear View Mirror Module																																																										
K	2009	ALL	Body	Instrument Panel Cluster																																																										
K	2009	ALL	Body	Left Side Object Detection Module																																																										
K	2009	ALL	Body	Lift Gate Module																																																										
K	2009	ALL	Body	Memory Seat Module																					V	V																																				
K	2009	ALL	Body	Park Assist Module																																																										
K	2009	ALL	Body	Passenger Door Switch																																																										
K	2009	ALL	Body	Passenger Presence System																																																										
K	2009	ALL	Body	Radio																																																										
K	2009	ALL	Body	Rear Heated Seat Module																																																										
K	2009	ALL	Body	Rear HVAC/RSA																																																										
K	2009	ALL	Body	Right Side Object Detection Module																																																										
K	2009	ALL	Body	Rollover Sensor																																																										
K	2009	ALL	Body	Supplemental Inflatable Restraint																			V																																							
K	2009	ALL	Body	Theft Deterrent Module		V																																																								
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																V					
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																V					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	ALL	Chassis	Electronic Brake Control Module													V																																													
K	2010	ALL	Chassis	Electronic Suspension Control																																																										
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	ALL	Body	Amplifier (Bose)																																																										
K	2010	ALL	Body	Assist Step Controller																																																										
K	2010	ALL	Body	Body Control Module			V																													V																											
K	2010	ALL	Body	Body Control Module (aux.)																																																										
K	2010	ALL	Body	Digital Radio Receiver																																																										
K	2010	ALL	Body	Driver Door Switch																																																										
K	2010	ALL	Body	HVAC Control Module																																																										
K	2010	ALL	Body	Inside Rear View Mirror Module																																																										
K	2010	ALL	Body	Instrument Panel Cluster																																																										
K	2010	ALL	Body	Left Side Object Detection Module																																																										
K	2010	ALL	Body	Lift Gate Module																																																										
K	2010	ALL	Body	Memory Seat Module																					V	V																																					
K	2010	ALL	Body	Park Assist Module																																																										
K	2010	ALL	Body	Passenger Door Switch																																																										
K	2010	ALL	Body	Passenger Presence System																																																										
K	2010	ALL	Body	Radio																																																										
K	2010	ALL	Body	Rear Heated Seat Module																																																										
K	2010	ALL	Body	Rear HVAC/RSA																																																										
K	2010	ALL	Body	Right Side Object Detection Module																																																										
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2010	ALL	Body	Theft Deterrent Module		V																																																								
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																										
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																										
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																										
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2010	SRX	Chassis	Electronic Brake Control Module																																																										
N	2010	SRX	Chassis	Parking Brake Control Module																																																										
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2010	SRX	Chassis	Suspension Control Module																																																										
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2010	SRX	Body	Passenger Presence Module																																																										
N	2010	SRX	Body	Instrument Cluster																																																										
N	2010	SRX	Body	Headlamp Control Module																																																										
N	2010	SRX	Body	Trailer Interface Control Module																																																										
N	2010	SRX	Body	Radio																																																										
N	2010	SRX	Body	Rear Audio Control Module																																																										
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2010	SRX	Body	Multimedia Player Interface Module																																																										
N	2010	SRX	Body	Mobile Telephone Control Module																																																										
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2010	SRX	Body	Liftgate Control Module																																																										
N	2010	SRX	Body	Seat Memory Control Module																																																										
N	2010	SRX	Body	Front Seat Heating Control Module																																																										
N	2010	SRX	Body	Rear Seat Heating Control Module																																																										
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2010	SRX	Body	Parking Assist Control Module																																																										
N	2010	SRX	Body	Steering Column Lock Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2011	SRX	Chassis	Electronic Brake Control Module																																																										
N	2011	SRX	Chassis	Parking Brake Control Module																																																										
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2011	SRX	Chassis	Suspension Control Module																																																										
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2011	SRX	Body	Passenger Presence Module																																																										
N	2011	SRX	Body	Instrument Cluster																																																										
N	2011	SRX	Body	Headlamp Control Module																																																										
N	2011	SRX	Body	Trailer Interface Control Module																																																										
N	2011	SRX	Body	Radio																																																										
N	2011	SRX	Body	Rear Audio Control Module																																																										
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2011	SRX	Body	Multimedia Player Interface Module																																																										
N	2011	SRX	Body	Mobile Telephone Control Module																																																										
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2011	SRX	Body	Liftgate Control Module																																																										
N	2011	SRX	Body	Seat Memory Control Module																																																										
N	2011	SRX	Body	Front Seat Heating Control Module																																																										
N	2011	SRX	Body	Rear Seat Heating Control Module																																																										
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2011	SRX	Body	Parking Assist Control Module																																																										
N	2011	SRX	Body	Steering Column Lock Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																										
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2012	SRX	Chassis	Electronic Brake Control Module																																																										
N	2012	SRX	Chassis	Parking Brake Control Module																																																										
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2012	SRX	Chassis	Suspension Control Module																																																										
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2012	SRX	Body	Passenger Presence Module																																																										
N	2012	SRX	Body	Instrument Cluster																																																										
N	2012	SRX	Body	Headlamp Control Module																																																										
N	2012	SRX	Body	Trailer Interface Control Module																																																										
N	2012	SRX	Body	Radio																																																										
N	2012	SRX	Body	Rear Audio Control Module																																																										
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2012	SRX	Body	Multimedia Player Interface Module																																																										
N	2012	SRX	Body	Mobile Telephone Control Module																																																										
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2012	SRX	Body	Liftgate Control Module																																																										
N	2012	SRX	Body	Seat Memory Control Module																																																										
N	2012	SRX	Body	Front Seat Heating Control Module																																																										
N	2012	SRX	Body	Rear Seat Heating Control Module																																																										
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2012	SRX	Body	Parking Assist Control Module																																																										
N	2012	SRX	Body	Steering Column Lock Control Module																																																										
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2013	SRX	Chassis	Electronic Brake Control Module																																																										
N	2013	SRX	Chassis	Parking Brake Control Module																																																										
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2013	SRX	Chassis	Suspension Control Module																																																										
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2013	SRX	Body	Passenger Presence Module																																																										
N	2013	SRX	Body	Instrument Cluster																																																										
N	2013	SRX	Body	Radio/HVAC Control																																																										
N	2013	SRX	Body	Active Safety Control Module																																																										
N	2013	SRX	Body	Headlamp Control Module																																																										
N	2013	SRX	Body	Trailer Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
N	2013	SRX	Body	Radio																																																										
N	2013	SRX	Body	Amplifier																																																										
N	2013	SRX	Body	Media Disc Player																																																										
N	2013	SRX	Body	Human Machine Interface Control Module																																																											
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																																											
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
N	2013	SRX	Body	Liftgate Control Module																																																											
N	2013	SRX	Body	Seat Memory Control Module																																																											
N	2013	SRX	Body	Rear Seat Heating Control Module																																																											
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2013	SRX	Body	Right Side Object Detection Control Module																																																											
N	2013	SRX	Body	Left Side Object Detection Control Module																																																											
N	2013	SRX	Body	Parking Assist Control Module																																																											
N	2013	SRX	Body	Frontview Camera Module																																																											
N	2013	SRX	Body	Steering Column Lock Control Module																																																											
N	2013	SRX	Body	Long Range Radar Sensor Module																																																											
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																											
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2014	SRX	Chassis	Electronic Brake Control Module																																																											
N	2014	SRX	Chassis	Parking Brake Control Module																																																											
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2014	SRX	Chassis	Suspension Control Module																																																											
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2014	SRX	Body	Passenger Presence Module																																																											
N	2014	SRX	Body	Instrument Cluster																																																											
N	2014	SRX	Body	Radio/HVAC Control																																																											
N	2014	SRX	Body	Active Safety Control Module																																																											
N	2014	SRX	Body	Headlamp Control Module																																																											
N	2014	SRX	Body	Trailer Interface Control Module																																																											
N	2014	SRX	Body	Radio																																																											
N	2014	SRX	Body	Amplifier																																																											
N	2014	SRX	Body	Media Disc Player																																																											
N	2014	SRX	Body	Human Machine Interface Control Module																																																											
N	2014	SRX	Body	Navigation Control Module																																																											
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																											
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
N	2014	SRX	Body	Liftgate Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2014	SRX	Body	Rear Seat Heating Control Module																																																											
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2014	SRX	Body	Right Side Object Detection Control Module																																																											
N	2014	SRX	Body	Left Side Object Detection Control Module																																																											
N	2014	SRX	Body	Parking Assist Control Module																																																											
N	2014	SRX	Body	Frontview Camera Module																																																											
N	2014	SRX	Body	Steering Column Lock Control Module																																																											
N	2014	SRX	Body	Long Range Radar Sensor Module																																																											
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																											
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2015	SRX	Chassis	Electronic Brake Control Module																																																											
N	2015	SRX	Chassis	Parking Brake Control Module																																																											
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2015	SRX	Chassis	Suspension Control Module																																																											
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2015	SRX	Body	Passenger Presence Module																																																											
N	2015	SRX	Body	Instrument Cluster																																																											
N	2015	SRX	Body	Radio/HVAC Control																																																											
N	2015	SRX	Body	Active Safety Control Module																																																											
N	2015	SRX	Body	Headlamp Control Module																																																											
N	2015	SRX	Body	Trailer Interface Control Module																																																											
N	2015	SRX	Body	Radio																																																											
N	2015	SRX	Body	Amplifier																																																											
N	2015	SRX	Body	Rear Audio Control Module																																																											
N	2015	SRX	Body	Media Disc Player																																																											
N	2015	SRX	Body	Human Machine Interface Control Module																																																											
N	2015	SRX	Body	Navigation Control Module																																																											
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																											
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
N	2015	SRX	Body	Liftgate Control Module																																																											
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																											
N	2015	SRX	Body	Rear Seat Heating Control Module																																																											
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2015	SRX	Body	Right Side Object Detection Control Module																																																											
N	2015	SRX	Body	Left Side Object Detection Control Module																																																											
N	2015	SRX	Body	Parking Assist Control Module																																																											
N	2015	SRX	Body	Frontview Camera Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
N	2015	SRX	Body	Steering Column Lock Control Module																																																												
N	2015	SRX	Body	Long Range Radar Sensor Module																																																												
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																												
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																												
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																												
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2016	SRX	Chassis	Electronic Brake Control Module																																																												
N	2016	SRX	Chassis	Parking Brake Control Module																																																												
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2016	SRX	Chassis	Suspension Control Module																																																												
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2016	SRX	Body	Passenger Presence Module																																																												
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																												
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																																												
N	2016	SRX	Body	Radio/HVAC Control																																																												
N	2016	SRX	Body	Active Safety Control Module																																																												
N	2016	SRX	Body	Headlamp Control Module																																																												
N	2016	SRX	Body	Trailer Interface Control Module																																																												
N	2016	SRX	Body	Radio																																																												
N	2016	SRX	Body	Amplifier																																																											
N	2016	SRX	Body	Rear Audio Control Module																																																												
N	2016	SRX	Body	Media Disc Player																																																												
N	2016	SRX	Body	Human Machine Interface Control Module																																																												
N	2016	SRX	Body	Navigation Control Module																																																												
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																												
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																																												
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
N	2016	SRX	Body	Liftgate Control Module																																																												
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																												
N	2016	SRX	Body	Rear Seat Heating Control Module																																																												
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																												
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																												
N	2016	SRX	Body	Right Side Object Detection Control Module																																																												
N	2016	SRX	Body	Left Side Object Detection Control Module																																																												
N	2016	SRX	Body	Parking Assist Control Module																																																												
N	2016	SRX	Body	Frontview Camera Module																																																												
N	2016	SRX	Body	Steering Column Lock Control Module																																																												
N	2016	SRX	Body	Long Range Radar Sensor Module																																																												
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																												
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																												
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																												
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																	V				
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																	V			
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
3	2011	ALL	Chassis	Electronic Brake Control Module													V																																													
3	2011	ALL	Chassis	Electronic Suspension Control																																																										
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2011	ALL	Body	Amplifier (Bose)																																																										
3	2011	ALL	Body	Assist Step Controller																																																										
3	2011	ALL	Body	Body Control Module			V																													V																											
3	2011	ALL	Body	Body Control Module (aux.)																																																										
3	2011	ALL	Body	Digital Radio Receiver																																																										
3	2011	ALL	Body	Driver Door Switch																																																										
3	2011	ALL	Body	HVAC Control Module																																																										
3	2011	ALL	Body	Inside Rear View Mirror Module																																																										
3	2011	ALL	Body	Instrument Panel Cluster																																																										
3	2011	ALL	Body	Left Side Object Detection Module																																																										
3	2011	ALL	Body	Lift Gate Module																																																										
3	2011	ALL	Body	Memory Seat Module																					V	V																																					
3	2011	ALL	Body	Park Assist Module																																																										
3	2011	ALL	Body	Passenger Door Switch																																																										
3	2011	ALL	Body	Passenger Presence System																																																										
3	2011	ALL	Body	Radio																																																										
3	2011	ALL	Body	Rear Heated Seat Module																																																										
3	2011	ALL	Body	Rear HVAC/RSA																																																										
3	2011	ALL	Body	Right Side Object Detection Module																																																										
3	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
3	2011	ALL	Body	Theft Deterrent Module		V																																																								
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																	V			
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																	V			
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
3	2012	ALL	Chassis	Electronic Brake Control Module													V																																													
3	2012	ALL	Chassis	Electronic Suspension Control																																																										
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2012	ALL	Body	Amplifier (Bose)																																																										
3	2012	ALL	Body	Assist Step Controller																																																										
3	2012	ALL	Body	Body Control Module			V																													V			V																							
3	2012	ALL	Body	Body Control Module (aux.)																																																										
3	2012	ALL	Body	Driver Door Switch																																																										
3	2012	ALL	Body	HVAC Control Module																																																										
3	2012	ALL	Body	Inside Rear View Mirror Module																																																										
3	2012	ALL	Body	Instrument Panel Cluster																																																										
3	2012	ALL	Body	Left Side Object Detection Module																																																										
3	2012	ALL	Body	Lift Gate Module																																																										
3	2012	ALL	Body	Memory Seat Module																					V	V																																					
3	2012	ALL	Body	Park Assist Module																																																										
3	2012	ALL	Body	Passenger Door Switch																																																										
3	2012	ALL	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
3	2012	ALL	Body	Radio																																																											
3	2012	ALL	Body	Rear Heated Seat Module																																																											
3	2012	ALL	Body	Rear HVAC/RSA																																																											
3	2012	ALL	Body	Right Side Object Detection Module																																																											
3	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
3	2012	ALL	Body	Theft Deterrent Module		V																																																									
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																V						
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
3	2013	ALL	Chassis	Electronic Brake Control Module													V																																														
3	2013	ALL	Chassis	Electronic Suspension Control																																																											
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																											
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																											
3	2013	ALL	Body	Amplifier (Bose)																																																											
3	2013	ALL	Body	Assist Step Controller																																																											
3	2013	ALL	Body	Body Control Module			V																													V			V																								
3	2013	ALL	Body	Body Control Module (aux.)																																																											
3	2013	ALL	Body	Driver Door Switch																																																											
3	2013	ALL	Body	HVAC Control Module																																																											
3	2013	ALL	Body	Inside Rear View Mirror Module																																																											
3	2013	ALL	Body	Instrument Panel Cluster																																																											
3	2013	ALL	Body	Left Side Object Detection Module																																																											
3	2013	ALL	Body	Lift Gate Module																																																											
3	2013	ALL	Body	Memory Seat Module																					V	V																																					
3	2013	ALL	Body	Park Assist Module																																																											
3	2013	ALL	Body	Passenger Door Switch																																																											
3	2013	ALL	Body	Passenger Presence System																																																											
3	2013	ALL	Body	Radio																																																											
3	2013	ALL	Body	Rear Heated Seat Module																																																											
3	2013	ALL	Body	Rear HVAC/RSA																																																											
3	2013	ALL	Body	Right Side Object Detection Module																																																											
3	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
3	2013	ALL	Body	Theft Deterrent Module		V																																																									
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																											
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																											
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																											
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																											
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																											
3	2014	Escalade	Chassis	Suspension Control Module																																																											
3	2014	Escalade	Body	Body Control Module																																																											
3	2014	Escalade	Body	Auxiliary Body Control Module																																																											
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
3	2014	Escalade	Body	Passenger Presence Module																																																											
3	2014	Escalade	Body	Instrument Cluster																																																											
3	2014	Escalade	Body	Radio																																																											
3	2014	Escalade	Body	Amplifier																																																											
3	2014	Escalade	Body	Rear Audio Control Module																																																											
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																											
3	2014	Escalade	Body	Personal Audio Link Control Module																																																											
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																											
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
3	2014	Escalade	Body	HVAC Control Module																																																										
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																										
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																										
3	2014	Escalade	Body	Liftgate Control Module																																																										
3	2014	Escalade	Body	Seat Memory Control Module																																																										
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																										
3	2014	Escalade	Body	Assist Step Control Module																																																										
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																										
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																										
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																										
3	2014	Escalade	Body	Parking Assist Control Module																																																										
3	2014	Escalade	Body	Theft Deterrent Module		V																																																								
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																										
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2014	Escalade ESV	Body	Body Control Module																																																										
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																										
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2014	Escalade ESV	Body	Passenger Presence Module																																																										
3	2014	Escalade ESV	Body	Instrument Cluster																																																										
3	2014	Escalade ESV	Body	Radio																																																										
3	2014	Escalade ESV	Body	Amplifier																																																										
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																										
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																										
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																										
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																										
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2014	Escalade ESV	Body	HVAC Control Module																																																										
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																										
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																										
3	2014	Escalade ESV	Body	Liftgate Control Module																																																										
3	2014	Escalade ESV	Body	Seat Memory Control Module																																																										
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																										
3	2014	Escalade ESV	Body	Assist Step Control Module																																																										
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																										
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																										
3	2014	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2014	Escalade ESV	Body	Theft Deterrent Module		V																																																								
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																										
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																										
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																									
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																										
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																										
3	2015	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2015	Escalade	Chassis	Parking Brake Control Module																																																										
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2015	Escalade	Chassis	Power Steering Control Module																																																										
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2015	Escalade	Chassis	Suspension Control Module																																																										
3	2015	Escalade	Body	Body Control Module																																																										
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2015	Escalade	Body	Passenger Presence Module																																																										
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2015	Escalade	Body	Instrument Cluster																																																										
3	2015	Escalade	Body	Radio/HVAC Control																																																										
3	2015	Escalade	Body	Active Safety Control Module																																																										
3	2015	Escalade	Body	Video Processing Control Module																																																										
3	2015	Escalade	Body	Radio																																																										
3	2015	Escalade	Body	Amplifier																																																										
3	2015	Escalade	Body	Media Disc Player																																																										
3	2015	Escalade	Body	Human Machine Interface Control Module																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2015	Escalade	Body	HVAC Control Module																																																										
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																										
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																										
3	2015	Escalade	Body	Keyless Entry Control Module																																																										
3	2015	Escalade	Body	Assist Step Control Module																																																										
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																										
3	2015	Escalade	Body	Parking Assist Control Module																																																										
3	2015	Escalade	Body	Frontview Camera Module																																																										
3	2015	Escalade	Body	Steering Column Lock Control Module																																																										
3	2015	Escalade	Body	Battery Energy Control Module																																																										
3	2015	Escalade	Body	Long Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																										
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																									
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																									
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																									
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																																									
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																									
3	2015	Escalade ESV	Chassis	Suspension Control Module																																																									
3	2015	Escalade ESV	Body	Body Control Module																																																									
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
3	2015	Escalade ESV	Body	Passenger Presence Module																																																									
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																									
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																									
3	2015	Escalade ESV	Body	Instrument Cluster																																																									
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																									
3	2015	Escalade ESV	Body	Active Safety Control Module																																																									
3	2015	Escalade ESV	Body	Video Processing Control Module																																																									
3	2015	Escalade ESV	Body	Radio																																																									
3	2015	Escalade ESV	Body	Amplifier																																																									
3	2015	Escalade ESV	Body	Media Disc Player																																																									
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																									
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																									
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																									
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																									
3	2015	Escalade ESV	Body	HVAC Control Module																																																									
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																									
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																									
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																									
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																									
3	2015	Escalade ESV	Body	Assist Step Control Module																																																									
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																									
3	2015	Escalade ESV	Body	Parking Assist Control Module																																																									
3	2015	Escalade ESV	Body	Frontview Camera Module																																																									
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																									
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																									
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																									
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																									
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																									
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																									
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
3	2016	Escalade	Chassis	Electronic Brake Control Module																																																									
3	2016	Escalade	Chassis	Parking Brake Control Module																																																									
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																									
3	2016	Escalade	Chassis	Power Steering Control Module																																																									
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																									
3	2016	Escalade	Chassis	Suspension Control Module																																																									
3	2016	Escalade	Body	Body Control Module																																																									
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
3	2016	Escalade	Body	Passenger Presence Module																																																									
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																									
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																									
3	2016	Escalade	Body	Instrument Cluster																																																									
3	2016	Escalade	Body	Radio/HVAC Control																																																									
3	2016	Escalade	Body	Active Safety Control Module																																																									
3	2016	Escalade	Body	Video Processing Control Module																																																									
3	2016	Escalade	Body	Radio																																																									
3	2016	Escalade	Body	Amplifier																																																									
3	2016	Escalade	Body	Media Disc Player																																																									
3	2016	Escalade	Body	Human Machine Interface Control Module																																																									
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																																									
3	2016	Escalade	Body	HVAC Control Module																																																									
3	2016	Escalade	Body	Liftgate Control Module																																																									
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																									
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																									
3	2016	Escalade	Body	Keyless Entry Control Module																																																									
3	2016	Escalade	Body	Assist Step Control Module																																																									
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																									
3	2016	Escalade	Body	Parking Assist Control Module																																																									
3	2016	Escalade	Body	Frontview Camera Module																																																									
3	2016	Escalade	Body	Steering Column Lock Control Module																																																									
3	2016	Escalade	Body	Long Range Radar Sensor Module																																																									
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																									
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																									
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																									
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																									
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																									
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																									
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																									
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																																									
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																									
3	2016	Escalade ESV	Chassis	Suspension Control Module																																																									
3	2016	Escalade ESV	Body	Body Control Module																																																									
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
3	2016	Escalade ESV	Body	Passenger Presence Module																																																									
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																									
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																									
3	2016	Escalade ESV	Body	Instrument Cluster																																																									
3	2016	Escalade ESV	Body	Radio Control																																																									
3	2016	Escalade ESV	Body	HVAC Control																																																									
3	2016	Escalade ESV	Body	Active Safety Control Module																																																									
3	2016	Escalade ESV	Body	Video Processing Control Module																																																									
3	2016	Escalade ESV	Body	Radio																																																									
3	2016	Escalade ESV	Body	Amplifier																																																									
3	2016	Escalade ESV	Body	Media Disc Player																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																										
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																										
3	2016	Escalade ESV	Body	HVAC Control Module																																																										
3	2016	Escalade ESV	Body	Liftgate Control Module																																																										
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																										
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																										
3	2016	Escalade ESV	Body	Assist Step Control Module																																																										
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2016	Escalade ESV	Body	Frontview Camera Module																																																										
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																										
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																V					
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																V					
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
4	2011	ALL	Chassis	Electronic Brake Control Module													V																																													
4	2011	ALL	Chassis	Electronic Suspension Control																																																										
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																										
4	2011	ALL	Body	Amplifier (Bose)																																																										
4	2011	ALL	Body	Assist Step Controller																																																										
4	2011	ALL	Body	Body Control Module			V																													V																										
4	2011	ALL	Body	Body Control Module (aux.)																																																										
4	2011	ALL	Body	Driver Door Switch																																																										
4	2011	ALL	Body	HVAC Control Module																																																										
4	2011	ALL	Body	Inside Rear View Mirror Module																																																										
4	2011	ALL	Body	Instrument Panel Cluster																																																										
4	2011	ALL	Body	Left Side Object Detection Module																																																										
4	2011	ALL	Body	Lift Gate Module																																																										
4	2011	ALL	Body	Memory Seat Module																					V	V																																				
4	2011	ALL	Body	Park Assist Module																																																										
4	2011	ALL	Body	Passenger Door Switch																																																										
4	2011	ALL	Body	Passenger Presence System																																																										
4	2011	ALL	Body	Radio																																																										
4	2011	ALL	Body	Rear Heated Seat Module																																																										
4	2011	ALL	Body	Rear HVAC/RSA																																																										
4	2011	ALL	Body	Right Side Object Detection Module																																																										
4	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
4	2011	ALL	Body	Theft Deterrent Module		V																																																								
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																V					
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																V					
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
4	2012	ALL	Chassis	Electronic Brake Control Module													V																																												
4	2012	ALL	Chassis	Electronic Suspension Control																																																										
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																										
4	2012	ALL	Body	Amplifier (Bose)																																																										
4	2012	ALL	Body	Assist Step Controller																																																										
4	2012	ALL	Body	Body Control Module			V																												V			V																								
4	2012	ALL	Body	Body Control Module (aux.)																																																										
4	2012	ALL	Body	Driver Door Switch																																																										
4	2012	ALL	Body	HVAC Control Module																																																										
4	2012	ALL	Body	Inside Rear View Mirror Module																																																										
4	2012	ALL	Body	Instrument Panel Cluster																																																										
4	2012	ALL	Body	Left Side Object Detection Module																																																										
4	2012	ALL	Body	Lift Gate Module																																																										
4	2012	ALL	Body	Memory Seat Module																					V	V																																					
4	2012	ALL	Body	Park Assist Module																																																										
4	2012	ALL	Body	Passenger Door Switch																																																										
4	2012	ALL	Body	Passenger Presence System																																																										
4	2012	ALL	Body	Radio																																																										
4	2012	ALL	Body	Rear Heated Seat Module																																																										
4	2012	ALL	Body	Rear HVAC/RSA																																																										
4	2012	ALL	Body	Right Side Object Detection Module																																																										
4	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
4	2012	ALL	Body	Theft Deterrent Module		V																																																								
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																V				
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
4	2013	ALL	Chassis	Electronic Brake Control Module													V																																													
4	2013	ALL	Chassis	Electronic Suspension Control																																																										
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																										
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																										
4	2013	ALL	Body	Amplifier (Bose)																																																										
4	2013	ALL	Body	Assist Step Controller																																																										
4	2013	ALL	Body	Body Control Module			V																												V			V																								
4	2013	ALL	Body	Body Control Module (aux.)																																																										
4	2013	ALL	Body	Driver Door Switch																																																										
4	2013	ALL	Body	HVAC Control Module																																																										
4	2013	ALL	Body	Inside Rear View Mirror Module																																																										
4	2013	ALL	Body	Instrument Panel Cluster																																																										
4	2013	ALL	Body	Left Side Object Detection Module																																																										
4	2013	ALL	Body	Lift Gate Module																																																										
4	2013	ALL	Body	Memory Seat Module																					V	V																																					
4	2013	ALL	Body	Park Assist Module																																																										
4	2013	ALL	Body	Passenger Door Switch																																																										
4	2013	ALL	Body	Passenger Presence System																																																										
4	2013	ALL	Body	Radio																																																										
4	2013	ALL	Body	Rear Heated Seat Module																																																										
4	2013	ALL	Body	Rear HVAC/RSA																																																										
4	2013	ALL	Body	Right Side Object Detection Module																																																										
4	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
4	2013	ALL	Body	Theft Deterrent Module		V																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade	Chassis	Suspension Control Module																																																										
4	2014	Escalade	Body	Body Control Module																																																										
4	2014	Escalade	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2014	Escalade	Body	Passenger Presence Module																																																										
4	2014	Escalade	Body	Instrument Cluster																																																										
4	2014	Escalade	Body	Radio																																																										
4	2014	Escalade	Body	Amplifier																																																										
4	2014	Escalade	Body	Rear Audio Control Module																																																										
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2014	Escalade	Body	HVAC Control Module																																																										
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Liftgate Control Module																																																										
4	2014	Escalade	Body	Seat Memory Control Module																																																										
4	2014	Escalade	Body	Rear Seat Heating Control Module																																																										
4	2014	Escalade	Body	Assist Step Control Module																																																										
4	2014	Escalade	Body	Right Side Object Detection Control Module																																																										
4	2014	Escalade	Body	Left Side Object Detection Control Module																																																										
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																																										
4	2014	Escalade	Body	Parking Assist Control Module																																																										
4	2014	Escalade	Body	Theft Deterrent Module		V																																																								
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2014	Escalade ESV	Body	Body Control Module																																																										
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2014	Escalade ESV	Body	Passenger Presence Module																																																										
4	2014	Escalade ESV	Body	Instrument Cluster																																																										
4	2014	Escalade ESV	Body	Radio																																																										
4	2014	Escalade ESV	Body	Amplifier																																																										
4	2014	Escalade ESV	Body	Rear Audio Control Module																																																										
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2014	Escalade ESV	Body	HVAC Control Module																																																										
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																										
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
4	2014	Escalade ESV	Body	Liftgate Control Module																																																											
4	2014	Escalade ESV	Body	Seat Memory Control Module																																																											
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																											
4	2014	Escalade ESV	Body	Assist Step Control Module																																																											
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																											
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																											
4	2014	Escalade ESV	Body	Parking Assist Control Module																																																											
4	2014	Escalade ESV	Body	Theft Deterrent Module		V																																																									
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																											
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																											
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																											
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																											
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																											
4	2015	Escalade	Chassis	Electronic Brake Control Module																																																											
4	2015	Escalade	Chassis	Parking Brake Control Module																																																											
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																											
4	2015	Escalade	Chassis	Power Steering Control Module																																																											
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																											
4	2015	Escalade	Chassis	Suspension Control Module																																																											
4	2015	Escalade	Body	Body Control Module																																																											
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
4	2015	Escalade	Body	Passenger Presence Module																																																											
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																											
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																											
4	2015	Escalade	Body	Instrument Cluster																																																											
4	2015	Escalade	Body	Radio/HVAC Control																																																											
4	2015	Escalade	Body	Active Safety Control Module																																																											
4	2015	Escalade	Body	Video Processing Control Module																																																											
4	2015	Escalade	Body	Radio																																																											
4	2015	Escalade	Body	Amplifier																																																											
4	2015	Escalade	Body	Media Disc Player																																																											
4	2015	Escalade	Body	Human Machine Interface Control Module																																																											
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																											
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																											
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																											
4	2015	Escalade	Body	HVAC Control Module																																																											
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																											
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																											
4	2015	Escalade	Body	Keyless Entry Control Module																																																											
4	2015	Escalade	Body	Assist Step Control Module																																																											
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
4	2015	Escalade	Body	Parking Assist Control Module																																																											
4	2015	Escalade	Body	Frontview Camera Module																																																												
4	2015	Escalade	Body	Steering Column Lock Control Module																																																												
4	2015	Escalade	Body	Battery Energy Control Module																																																												
4	2015	Escalade	Body	Long Range Radar Sensor Module																																																												
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																												
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																												
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																												
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																												
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																												
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																												
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																												
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																												
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																												
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																																												
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																												
4	2015	Escalade ESV	Chassis	Suspension Control Module																																																												
4	2015	Escalade ESV	Body	Body Control Module																																																												
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
4	2015	Escalade ESV	Body	Passenger Presence Module																																																												
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																												
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																												
4	2015	Escalade ESV	Body	Instrument Cluster																																																												
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																												
4	2015	Escalade ESV	Body	Active Safety Control Module																																																												
4	2015	Escalade ESV	Body	Video Processing Control Module																																																												
4	2015	Escalade ESV	Body	Radio																																																												
4	2015	Escalade ESV	Body	Amplifier																																																												
4	2015	Escalade ESV	Body	Media Disc Player																																																												
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																												
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																												
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																												
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																												
4	2015	Escalade ESV	Body	HVAC Control Module																																																												
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																											
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																											
4	2015	Escalade ESV	Body	Assist Step Control Module																																																											
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
4	2015	Escalade ESV	Body	Parking Assist Control Module																																																											
4	2015	Escalade ESV	Body	Frontview Camera Module																																																											
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
4	2016	Escalade	Chassis	Electronic Brake Control Module																																																										
4	2016	Escalade	Chassis	Parking Brake Control Module																																																										
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2016	Escalade	Chassis	Power Steering Control Module																																																										
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2016	Escalade	Chassis	Suspension Control Module																																																										
4	2016	Escalade	Body	Body Control Module																																																										
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2016	Escalade	Body	Passenger Presence Module																																																										
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2016	Escalade	Body	Instrument Cluster																																																										
4	2016	Escalade	Body	Radio/HVAC Control																																																										
4	2016	Escalade	Body	Active Safety Control Module																																																										
4	2016	Escalade	Body	Video Processing Control Module																																																										
4	2016	Escalade	Body	Radio																																																										
4	2016	Escalade	Body	Amplifier																																																										
4	2016	Escalade	Body	Media Disc Player																																																										
4	2016	Escalade	Body	Human Machine Interface Control Module																																																										
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																																										
4	2016	Escalade	Body	HVAC Control Module																																																										
4	2016	Escalade	Body	Liftgate Control Module																																																										
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																										
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																										
4	2016	Escalade	Body	Keyless Entry Control Module																																																										
4	2016	Escalade	Body	Assist Step Control Module																																																										
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																										
4	2016	Escalade	Body	Parking Assist Control Module																																																										
4	2016	Escalade	Body	Frontview Camera Module																																																										
4	2016	Escalade	Body	Steering Column Lock Control Module																																																										
4	2016	Escalade	Body	Long Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																										
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																																										
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2016	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2016	Escalade ESV	Body	Body Control Module																																																										
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2016	Escalade ESV	Body	Passenger Presence Module																																																										
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2016	Escalade ESV	Body	Instrument Cluster																																																										
4	2016	Escalade ESV	Body	Radio Control																																																										
4	2016	Escalade ESV	Body	HVAC Control																																																										
4	2016	Escalade ESV	Body	Active Safety Control Module																																																										
4	2016	Escalade ESV	Body	Video Processing Control Module																																																										
4	2016	Escalade ESV	Body	Radio																																																										
4	2016	Escalade ESV	Body	Amplifier																																																										
4	2016	Escalade ESV	Body	Media Disc Player																																																										
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																										
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																										
4	2016	Escalade ESV	Body	HVAC Control Module																																																										
4	2016	Escalade ESV	Body	Liftgate Control Module																																																										
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																										
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																										
4	2016	Escalade ESV	Body	Assist Step Control Module																																																										
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
4	2016	Escalade ESV	Body	Parking Assist Control Module																																																										
4	2016	Escalade ESV	Body	Frontview Camera Module																																																										
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																										
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module			V		V																																																					
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module					V																																																					
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module			V		V																																																					
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module					V																																																					
ALL	2004	Hearse	Chassis	DRP/ABS/TCS																																																											
ALL	2004	Hearse	Chassis	Magna Steer																																																										
ALL	2004	Hearse	Chassis	Rear Integration Module																																																										
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																										
ALL	2004	Hearse	Body	Amplifier (Delco)																																																										
ALL	2004	Hearse	Body	Dash Integration Module																																																										
ALL	2004	Hearse	Body	Driver Door Switch																																																										
ALL	2004	Hearse	Body	Driver Door Module																																																										
ALL	2004	Hearse	Body	Passenger Door Module																																																										
ALL	2004	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2004	Hearse	Body	Instrument Panel Module																																																										
ALL	2004	Hearse	Body	Personalization																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
ALL	2004	Hearse	Body	Radio							V	V																																																	
ALL	2004	Hearse	Body	Rear Integration Module																																							V																		
ALL	2004	Hearse	Body	Remote Function Actuation																																								V																	
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																	V																																								
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																																									
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module			V		V																																																				
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module					V																																																				
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module			V		V																																																				
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module					V																																																				
ALL	2004	Limousine	Chassis	DRP/ABS/TCS																																																										
ALL	2004	Limousine	Chassis	Magna Steer																																																									
ALL	2004	Limousine	Chassis	Rear Integration Module																																																									
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																									
ALL	2004	Limousine	Body	Amplifier (Delco)																																																									
ALL	2004	Limousine	Body	Dash Integration Module																																																									
ALL	2004	Limousine	Body	Driver Door Switch																																																									
ALL	2004	Limousine	Body	Driver Door Module																																																									
ALL	2004	Limousine	Body	Passenger Door Module																																																									
ALL	2004	Limousine	Body	Left Mid Door Module																																																									
ALL	2004	Limousine	Body	Left Rear Door Module																																																									
ALL	2004	Limousine	Body	Right Mid Door Module																																																									
ALL	2004	Limousine	Body	Right Rear Door Module																																																									
ALL	2004	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2004	Limousine	Body	Instrument Panel Module																																																									
ALL	2004	Limousine	Body	Memory Seat Module																																																									
ALL	2004	Limousine	Body	Navigation Radio							V																																																		
ALL	2004	Limousine	Body	Personalization																																																									
ALL	2004	Limousine	Body	Radio							V	V																																																	
ALL	2004	Limousine	Body	Rear Climate Control Panel																																																									
ALL	2004	Limousine	Body	Rear Integration Module																																							V																		
ALL	2004	Limousine	Body	Remote Function Actuation																																								V																	
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																	V																																								
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																																									
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module			V		V																																																				
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module					V																																																				
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module			V		V																																																				
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module					V																																																				
ALL	2005	Hearse	Chassis	DRP/ABS/TCS																																																										
ALL	2005	Hearse	Chassis	Magna Steer																																																									
ALL	2005	Hearse	Chassis	Rear Integration Module																																																									
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																									
ALL	2005	Hearse	Body	Amplifier (Delco)																																																									
ALL	2005	Hearse	Body	Dash Integration Module																																																									
ALL	2005	Hearse	Body	Driver Door Switch																																																									
ALL	2005	Hearse	Body	Driver Door Module																																																									
ALL	2005	Hearse	Body	Passenger Door Module																																																									
ALL	2005	Hearse	Body	Instrument Panel Cluster																																																									
ALL	2005	Hearse	Body	Instrument Panel Module																																																									
ALL	2005	Hearse	Body	Personalization																																																									
ALL	2005	Hearse	Body	Radio							V	V																																																	
ALL	2005	Hearse	Body	Rear Integration Module																																							V																		

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
ALL	2005	Hearse	Body	Remote Function Actuation																																																										
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint	V																																																									
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																																										
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module			V		V																																																					
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module					V																																																					
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module			V		V																																																					
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module					V																																																					
ALL	2005	Limousine	Chassis	DRP/ABS/TCS																																																										
ALL	2005	Limousine	Chassis	Magna Steer																																																										
ALL	2005	Limousine	Chassis	Rear Integration Module																																																										
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																										
ALL	2005	Limousine	Body	Amplifier (Delco)																																																										
ALL	2005	Limousine	Body	Dash Integration Module																																																										
ALL	2005	Limousine	Body	Driver Door Switch																																																										
ALL	2005	Limousine	Body	Driver Door Module																																																										
ALL	2005	Limousine	Body	Passenger Door Module																																																										
ALL	2005	Limousine	Body	Left Mid Door Module																																																										
ALL	2005	Limousine	Body	Left Rear Door Module																																																										
ALL	2005	Limousine	Body	Right Mid Door Module																																																										
ALL	2005	Limousine	Body	Right Rear Door Module																																																										
ALL	2005	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2005	Limousine	Body	Instrument Panel Module																																																										
ALL	2005	Limousine	Body	Memory Seat Module																																																										
ALL	2005	Limousine	Body	Navigation Radio							V																																																			
ALL	2005	Limousine	Body	Personalization																																																										
ALL	2005	Limousine	Body	Radio							V	V																																																		
ALL	2005	Limousine	Body	Rear Climate Control Panel																																																										
ALL	2005	Limousine	Body	Rear Integration Module																																							V																			
ALL	2005	Limousine	Body	Remote Function Actuation																																																										
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint	V																V																																									
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																																										
ALL	2006	Hearse	Powertrain	Engine Control Module					V																																																					V
ALL	2006	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2006	Hearse	Chassis	Electronic Brake Control Module										V	V	V																																														
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2006	Hearse	Body	Amplifier (Bose)																																																										
ALL	2006	Hearse	Body	Body Control Module			V																													V																										
ALL	2006	Hearse	Body	Digital Radio Receiver																																																										
ALL	2006	Hearse	Body	Driver Door Switch																																																										
ALL	2006	Hearse	Body	Driver Position Module																					V	V																																				
ALL	2006	Hearse	Body	HVAC Control Module																												V																														
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2006	Hearse	Body	Passenger Door Switch																																																										
ALL	2006	Hearse	Body	Passenger Presence System																																																										
ALL	2006	Hearse	Body	Radio																																																										
ALL	2006	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																			V																																							
ALL	2006	Hearse	Body	Theft Deterrent Module		V																																																								
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																																V	V	V								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
ALL	2006	Limousine	Powertrain	Engine Control Module					V																																																				V
ALL	2006	Limousine	Powertrain	Transmission Control Module																																																									
ALL	2006	Limousine	Chassis	Electronic Brake Control Module											V	V	V																																											
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																									
ALL	2006	Limousine	Body	Amplifier (Bose)																																																									
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																									
ALL	2006	Limousine	Body	Body Control Module			V																		V																																					
ALL	2006	Limousine	Body	Digital Radio Receiver																																																										
ALL	2006	Limousine	Body	Driver Door Switch																																																										
ALL	2006	Limousine	Body	Driver Position Module																					V	V																																					
ALL	2006	Limousine	Body	HVAC Control Module																													V																															
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2006	Limousine	Body	Passenger Door Switch																																																										
ALL	2006	Limousine	Body	Passenger Presence System																																																										
ALL	2006	Limousine	Body	Radio																																																										
ALL	2006	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																			V																																							
ALL	2006	Limousine	Body	Theft Deterrent Module		V																																																									
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																																V	V	V						
ALL	2007	Hearse	Powertrain	Engine Control Module					V																																														V				V
ALL	2007	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2007	Hearse	Chassis	Electronic Brake Control Module											V	V	V																																												
ALL	2007	Hearse	Body	Amplifier (Bose)																																																										
ALL	2007	Hearse	Body	Body Control Module			V																													V			V																							
ALL	2007	Hearse	Body	Digital Radio Receiver																																																										
ALL	2007	Hearse	Body	Driver Door Switch																																																										
ALL	2007	Hearse	Body	Driver Position Module																					V	V																																					
ALL	2007	Hearse	Body	HVAC Control Module																													V																															
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2007	Hearse	Body	Passenger Door Switch																																																										
ALL	2007	Hearse	Body	Passenger Presence System																																																										
ALL	2007	Hearse	Body	Radio																																																										
ALL	2007	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																			V																																							
ALL	2007	Hearse	Body	Theft Deterrent Module		V																																																									
ALL	2007	Limousine	Powertrain	Engine Control Module					V																																														V				V
ALL	2007	Limousine	Powertrain	Transmission Control Module																																																											
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																											
ALL	2007	Limousine	Chassis	Electronic Brake Control Module											V	V	V																																												
ALL	2007	Limousine	Body	Amplifier (Bose)																																																										
ALL	2007	Limousine	Body	Aux. HVAC Control Module																													V																															
ALL	2007	Limousine	Body	Body Control Module			V																													V			V																							
ALL	2007	Limousine	Body	Digital Radio Receiver																																																										
ALL	2007	Limousine	Body	Driver Door Switch																																																										
ALL	2007	Limousine	Body	Driver Position Module																					V	V																																					
ALL	2007	Limousine	Body	HVAC Control Module																													V																															
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																								
ALL	2007	Limousine	Body	Passenger Door Switch																																																								
ALL	2007	Limousine	Body	Passenger Presence System																																																								
ALL	2007	Limousine	Body	Radio																																																								
ALL	2007	Limousine	Body	Rear Heated Seat Module																																																								
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																			V																																					
ALL	2007	Limousine	Body	Theft Deterrent Module		V																																																							
ALL	2008	Hearse	Powertrain	Engine Control Module					V																																															V			V
ALL	2008	Hearse	Powertrain	Transmission Control Module																																																								
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																								
ALL	2008	Hearse	Chassis	Electronic Brake Control Module											V	V	V																																										
ALL	2008	Hearse	Body	Amplifier (Bose)																																																								
ALL	2008	Hearse	Body	Body Control Module			V																													V			V																					
ALL	2008	Hearse	Body	Climate Control Seat Module																																																								
ALL	2008	Hearse	Body	Digital Radio Receiver																																																								
ALL	2008	Hearse	Body	Driver Door Switch																																																								
ALL	2008	Hearse	Body	Driver Position Module																					V	V																																		
ALL	2008	Hearse	Body	HVAC Control Module																																																								
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																								
ALL	2008	Hearse	Body	Passenger Door Switch																																																								
ALL	2008	Hearse	Body	Passenger Presence System																																																								
ALL	2008	Hearse	Body	Radio																																																								
ALL	2008	Hearse	Body	Rear Heated Seat Module																																																								
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																			V																																					
ALL	2008	Hearse	Body	Theft Deterrent Module		V																																																							
ALL	2008	Limousine	Powertrain	Engine Control Module					V																																															V			V
ALL	2008	Limousine	Powertrain	Transmission Control Module																																																								
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																								
ALL	2008	Limousine	Chassis	Electronic Brake Control Module											V	V	V																																										
ALL	2008	Limousine	Body	Amplifier (Bose)																																																								
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																								
ALL	2008	Limousine	Body	Body Control Module			V																													V			V																					
ALL	2008	Limousine	Body	Climate Control Seat Module																																																								
ALL	2008	Limousine	Body	Digital Radio Receiver																																																								
ALL	2008	Limousine	Body	Driver Door Switch																																																								
ALL	2008	Limousine	Body	Driver Position Module																					V	V																																		
ALL	2008	Limousine	Body	HVAC Control Module																																																								
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																								
ALL	2008	Limousine	Body	Passenger Door Switch																																																								
ALL	2008	Limousine	Body	Passenger Presence System																																																								
ALL	2008	Limousine	Body	Radio																																																								
ALL	2008	Limousine	Body	Rear Heated Seat Module																																																								
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																			V																																					
ALL	2008	Limousine	Body	Theft Deterrent Module		V																																																							
ALL	2009	Hearse	Powertrain	Engine Control Module					V																																															V		V	V
ALL	2009	Hearse	Powertrain	Transmission Control Module																																																								
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																								
ALL	2009	Hearse	Chassis	Electronic Brake Control Module											V	V	V																																										
ALL	2009	Hearse	Body	Amplifier (Bose)																																																								
ALL	2009	Hearse	Body	Body Control Module			V																													V			V																					
ALL	2009	Hearse	Body	Climate Control Seat Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
ALL	2009	Hearse	Body	Digital Radio Receiver																																																								
ALL	2009	Hearse	Body	Driver Door Switch																																																								
ALL	2009	Hearse	Body	Driver Position Module																					V	V																																		
ALL	2009	Hearse	Body	HVAC Control Module																																																								
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																								
ALL	2009	Hearse	Body	Passenger Door Switch																																																								
ALL	2009	Hearse	Body	Passenger Presence System																																																								
ALL	2009	Hearse	Body	Radio																																																								
ALL	2009	Hearse	Body	Rear Heated Seat Module																																																								
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																			V																																					
ALL	2009	Hearse	Body	Theft Deterrent Module		V																																																						
ALL	2009	Limousine	Powertrain	Engine Control Module					V																																															V		V	V
ALL	2009	Limousine	Powertrain	Transmission Control Module																																																								
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																								
ALL	2009	Limousine	Chassis	Electronic Brake Control Module											V	V	V																																											
ALL	2009	Limousine	Body	Amplifier (Bose)																																																								
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																								
ALL	2009	Limousine	Body	Body Control Module			V																													V			V																					
ALL	2009	Limousine	Body	Climate Control Seat Module																																																								
ALL	2009	Limousine	Body	Digital Radio Receiver																																																								
ALL	2009	Limousine	Body	Driver Door Switch																																																								
ALL	2009	Limousine	Body	Driver Position Module																					V	V																																		
ALL	2009	Limousine	Body	HVAC Control Module																																																								
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																								
ALL	2009	Limousine	Body	Passenger Door Switch																																																								
ALL	2009	Limousine	Body	Passenger Presence System																																																								
ALL	2009	Limousine	Body	Radio																																																								
ALL	2009	Limousine	Body	Rear Heated Seat Module																																																								
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																			V																																					
ALL	2009	Limousine	Body	Theft Deterrent Module		V																																																						
ALL	2010	Hearse	Powertrain	Engine Control Module					V																																															V		V	V
ALL	2010	Hearse	Powertrain	Transmission Control Module																																																								
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																								
ALL	2010	Hearse	Chassis	Electronic Brake Control Module											V	V	V																																											
ALL	2010	Hearse	Body	Amplifier (Bose)																																																								
ALL	2010	Hearse	Body	Body Control Module			V																													V			V																					
ALL	2010	Hearse	Body	Climate Control Seat Module																																																								
ALL	2010	Hearse	Body	Digital Radio Receiver																																																								
ALL	2010	Hearse	Body	Driver Door Switch																																																								
ALL	2010	Hearse	Body	Driver Position Module																					V	V																																		
ALL	2010	Hearse	Body	HVAC Control Module																																																								
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																								
ALL	2010	Hearse	Body	Passenger Door Switch																																																								
ALL	2010	Hearse	Body	Passenger Presence System																																																								
ALL	2010	Hearse	Body	Radio																																																								
ALL	2010	Hearse	Body	Rear Heated Seat Module																																																								
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																			V																																					
ALL	2010	Hearse	Body	Theft Deterrent Module		V																																																						
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																																V		V						
ALL	2010	Limousine	Powertrain	Engine Control Module					V																																															V		V	V
ALL	2010	Limousine	Powertrain	Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																									
ALL	2010	Limousine	Chassis	Electronic Brake Control Module											V	V	V																																												
ALL	2010	Limousine	Body	Amplifier (Bose)																																																										
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2010	Limousine	Body	Body Control Module			V																		V											V			V																							
ALL	2010	Limousine	Body	Climate Control Seat Module																																																										
ALL	2010	Limousine	Body	Digital Radio Receiver																																																										
ALL	2010	Limousine	Body	Driver Door Switch																																																										
ALL	2010	Limousine	Body	Driver Position Module																					V	V																																					
ALL	2010	Limousine	Body	HVAC Control Module																																																										
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2010	Limousine	Body	Passenger Door Switch																																																										
ALL	2010	Limousine	Body	Passenger Presence System																																																										
ALL	2010	Limousine	Body	Radio																																																										
ALL	2010	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																			V																																							
ALL	2010	Limousine	Body	Theft Deterrent Module		V																																																									
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																															V		V							
ALL	2011	Hearse	Powertrain	Engine Control Module					V																																														V		V	V
ALL	2011	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2011	Hearse	Chassis	Electronic Brake Control Module											V	V	V																																												
ALL	2011	Hearse	Body	Amplifier (Bose)																																																										
ALL	2011	Hearse	Body	Body Control Module			V																		V											V			V																							
ALL	2011	Hearse	Body	Climate Control Seat Module																																																										
ALL	2011	Hearse	Body	Digital Radio Receiver																																																										
ALL	2011	Hearse	Body	Driver Door Switch																																																										
ALL	2011	Hearse	Body	Driver Position Module																					V	V																																					
ALL	2011	Hearse	Body	HVAC Control Module																																																										
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2011	Hearse	Body	Passenger Door Switch																																																										
ALL	2011	Hearse	Body	Passenger Presence System																																																										
ALL	2011	Hearse	Body	Radio																																																										
ALL	2011	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																			V																																							
ALL	2011	Hearse	Body	Theft Deterrent Module		V																																																									
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																															V		V							
ALL	2011	Limousine	Powertrain	Engine Control Module					V																																														V		V	V
ALL	2011	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2011	Limousine	Chassis	Electronic Brake Control Module											V	V	V																																												
ALL	2011	Limousine	Body	Amplifier (Bose)																																																										
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2011	Limousine	Body	Body Control Module			V																		V											V			V																							
ALL	2011	Limousine	Body	Climate Control Seat Module																																																										
ALL	2011	Limousine	Body	Digital Radio Receiver																																																										
ALL	2011	Limousine	Body	Driver Door Switch																																																										
ALL	2011	Limousine	Body	Driver Position Module																					V	V																																					
ALL	2011	Limousine	Body	HVAC Control Module																																																										
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2011	Limousine	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
ALL	2011	Limousine	Body	Passenger Presence System																																																								
ALL	2011	Limousine	Body	Radio																																																								
ALL	2011	Limousine	Body	Rear Heated Seat Module																																																								
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																			V																																					
ALL	2011	Limousine	Body	Theft Deterrent Module		V																																																							
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																															V		V						

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Instrument Panel Cluster																																																										
C	2004	ALL	Body	OnStar																																																										
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Base Radio																																																										
C	2004	ALL	Body	Uplevel Radio																																																										
C	2004	ALL	Body	Navigation Radio																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																										
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																										
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	ESC																																																									
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2005	ALL	Chassis	VSES																																																									
C	2005	ALL	Body	Amplifier (Bose)																																																										
C	2005	ALL	Body	Body Control Module																																																										
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																																										
C	2005	ALL	Body	Driver Seat Module																																																										
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																											
C	2005	ALL	Body	Instrument Panel Cluster																																																											
C	2005	ALL	Body	Passenger Door Module																																																											
C	2005	ALL	Body	Passenger Presence System																																																											
C	2005	ALL	Body	Base Radio																																																											
C	2005	ALL	Body	Uplevel Radio																																																											
C	2005	ALL	Body	Navigation Radio																																																											
C	2005	ALL	Body	Rear Aux. Climate Module																																																											
C	2005	ALL	Body	Rear HVAC																																																											
C	2005	ALL	Body	Rear Seat Audio																																																											
C	2005	ALL	Body	Remote Function Actuation																																																											
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																											
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																											
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																											
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2006	ALL	Chassis	ESC																																																										
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																										
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																										
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module				V																																																						
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																								
C	2007	ALL	Chassis	Electronic Brake Control Module																																																										
C	2007	ALL	Chassis	Electronic Suspension Control																																																										
C	2007	ALL	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2007	ALL	Body	Assist Step Controller																																																									
C	2007	ALL	Body	Body Control Module														V	V	V	V	V	V	V		V	V			V																															
C	2007	ALL	Body	Body Control Module (aux.)																																																									
C	2007	ALL	Body	Digital Radio Receiver																																																									
C	2007	ALL	Body	Driver Door Switch																																																									
C	2007	ALL	Body	HVAC Control Module																												V	V																												
C	2007	ALL	Body	Inside Rear View Mirror Module																																																									
C	2007	ALL	Body	Instrument Panel Cluster																																																									
C	2007	ALL	Body	Lift Gate Module																																																									
C	2007	ALL	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																			
C	2007	ALL	Body	Park Assist Module																																							V	V	V																
C	2007	ALL	Body	Passenger Door Switch																																																									
C	2007	ALL	Body	Passenger Presence System																																										V															
C	2007	ALL	Body	Radio																																																									
C	2007	ALL	Body	Rear Heated Seat Module																																	V				V																				
C	2007	ALL	Body	Rear HVAC/RSA																																																									
C	2007	ALL	Body	Rollover Sensor																																																									
C	2007	ALL	Body	Supplemental Inflatable Restraint																																										V									V						
C	2007	ALL	Body	Theft Deterrent Module																																																									
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module	V			V																																																					
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																							
C	2008	ALL	Chassis	Electronic Brake Control Module																																																									
C	2008	ALL	Chassis	Electronic Suspension Control																																																									
C	2008	ALL	Chassis	Trailer Brake Control Module																																																									
C	2008	ALL	Body	Amplifier (Bose)																																																									
C	2008	ALL	Body	Assist Step Controller																																																									
C	2008	ALL	Body	Body Control Module														V	V	V	V	V	V	V	V	V	V			V																															
C	2008	ALL	Body	Body Control Module (aux.)																																																									
C	2008	ALL	Body	Digital Radio Receiver																																																									
C	2008	ALL	Body	Driver Door Switch																																																									
C	2008	ALL	Body	HVAC Control Module																												V	V																												
C	2008	ALL	Body	Inside Rear View Mirror Module																																																									
C	2008	ALL	Body	Instrument Panel Cluster																																																									
C	2008	ALL	Body	Lift Gate Module																																																									
C	2008	ALL	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																			
C	2008	ALL	Body	Park Assist Module																																							V	V	V																
C	2008	ALL	Body	Passenger Door Switch																																																									
C	2008	ALL	Body	Passenger Presence System																																										V															
C	2008	ALL	Body	Radio																																																									
C	2008	ALL	Body	Rear Heated Seat Module																																	V				V																				
C	2008	ALL	Body	Rear HVAC/RSA																																																									
C	2008	ALL	Body	Rollover Sensor																																																									
C	2008	ALL	Body	Supplemental Inflatable Restraint																																										V									V						
C	2008	ALL	Body	Theft Deterrent Module																																																									
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																					
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																							
C	2009	ALL	Chassis	Electronic Brake Control Module																																																									
C	2009	ALL	Chassis	Electronic Suspension Control																																																									
C	2009	ALL	Chassis	Trailer Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2009	ALL	Body	Amplifier (Bose)																																																										
C	2009	ALL	Body	Assist Step Controller																																																										
C	2009	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2009	ALL	Body	Body Control Module (aux.)																																																										
C	2009	ALL	Body	Digital Radio Receiver																																																										
C	2009	ALL	Body	Driver Door Switch																																																										
C	2009	ALL	Body	HVAC Control Module																												V	V																															
C	2009	ALL	Body	Inside Rear View Mirror Module																																																										
C	2009	ALL	Body	Instrument Panel Cluster																																																										
C	2009	ALL	Body	Left Side Object Detection Module																																								V					V													
C	2009	ALL	Body	Lift Gate Module																																																										
C	2009	ALL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																					
C	2009	ALL	Body	Park Assist Module																																							V	V	V																	
C	2009	ALL	Body	Passenger Door Switch																																																										
C	2009	ALL	Body	Passenger Presence System																																										V																
C	2009	ALL	Body	Radio																																																										
C	2009	ALL	Body	Rear Heated Seat Module																																	V				V																					
C	2009	ALL	Body	Rear HVAC/RSA																																																										
C	2009	ALL	Body	Right Side Object Detection Module																																								V					V													
C	2009	ALL	Body	Rollover Sensor																																																										
C	2009	ALL	Body	Supplemental Inflatable Restraint																																										V										V						
C	2009	ALL	Body	Theft Deterrent Module																																																										
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																							
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																									
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																							
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																									
C	2010	ALL	Chassis	Electronic Brake Control Module																																																											
C	2010	ALL	Chassis	Electronic Suspension Control																																																											
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	ALL	Body	Amplifier (Bose)																																																											
C	2010	ALL	Body	Assist Step Controller																																																											
C	2010	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2010	ALL	Body	Body Control Module (aux.)																																																											
C	2010	ALL	Body	Digital Radio Receiver																																																											
C	2010	ALL	Body	Driver Door Switch																																																											
C	2010	ALL	Body	HVAC Control Module																												V	V																															
C	2010	ALL	Body	Inside Rear View Mirror Module																																																											
C	2010	ALL	Body	Instrument Panel Cluster																																																											
C	2010	ALL	Body	Left Side Object Detection Module																																								V					V													
C	2010	ALL	Body	Lift Gate Module																																																											
C	2010	ALL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																					
C	2010	ALL	Body	Park Assist Module																																							V	V	V																	
C	2010	ALL	Body	Passenger Door Switch																																																											
C	2010	ALL	Body	Passenger Presence System																																										V																
C	2010	ALL	Body	Radio																																																										
C	2010	ALL	Body	Rear Heated Seat Module																																	V				V																					
C	2010	ALL	Body	Rear HVAC/RSA																																																											
C	2010	ALL	Body	Right Side Object Detection Module																																								V					V													
C	2010	ALL	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2010	ALL	Body	Theft Deterrent Module																																																										
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																											
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																																											
E	2004	ALL	Chassis	Electronic Suspension Control																																																											
E	2004	ALL	Chassis	Tire Pressure Monitor																																																											
E	2004	ALL	Chassis	VES																																																											
E	2004	ALL	Body	Amplifier (Bose)																																																											
E	2004	ALL	Body	Amplifier (Delco)																																																											
E	2004	ALL	Body	Climate Control Panel																																																											
E	2004	ALL	Body	Dash Integration Module																																																											
E	2004	ALL	Body	Disc Player and Video Display																																																											
E	2004	ALL	Body	Driver Door Switch																																																											
E	2004	ALL	Body	Driver Door Module																																																											
E	2004	ALL	Body	Passenger Door Module																																																											
E	2004	ALL	Body	Left Rear Door Module																																																											
E	2004	ALL	Body	Right Rear Door Module																																																											
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																											
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																											
E	2004	ALL	Body	Instrument Panel Cluster																																																											
E	2004	ALL	Body	Memory Seat Module																																																											
E	2004	ALL	Body	OnStar																																																											
E	2004	ALL	Body	Personalization																																																											
E	2004	ALL	Body	Base Radio																																																											
E	2004	ALL	Body	Navigation Radio																																																											
E	2004	ALL	Body	Rear Integration Module																																																											
E	2004	ALL	Body	Rear Seat Module																																																												
E	2004	ALL	Body	Remote Function Actuation																																																												
E	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2004	ALL	Body	TV Antenna Module																																																												
E	2004	ALL	Body	Vehicle Theft Deterrent																																																												
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																																												
E	2005	ALL	Chassis	Electronic Suspension Control																																																												
E	2005	ALL	Chassis	Tire Pressure Monitor																																																												
E	2005	ALL	Chassis	VES																																																											
E	2005	ALL	Body	Amplifier (Bose)																																																											
E	2005	ALL	Body	Amplifier (Delco)																																																												
E	2005	ALL	Body	Climate Control Panel																																																												
E	2005	ALL	Body	Dash Integration Module																																																												
E	2005	ALL	Body	Disc Player and Video Display																																																												
E	2005	ALL	Body	Driver Door Switch																																																												
E	2005	ALL	Body	Driver Door Module																																																												
E	2005	ALL	Body	Passenger Door Module																																																												
E	2005	ALL	Body	Left Rear Door Module																																																												
E	2005	ALL	Body	Right Rear Door Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2005	ALL	Body	Instrument Panel Cluster																																																										
E	2005	ALL	Body	Memory Seat Module																																																										
E	2005	ALL	Body	Personalization																																																										
E	2005	ALL	Body	Base Radio																																																										
E	2005	ALL	Body	Navigation Radio																																																										
E	2005	ALL	Body	Rear Integration Module																																																										
E	2005	ALL	Body	Rear Seat Module																																																										
E	2005	ALL	Body	Remote Function Actuation																																																										
E	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2005	ALL	Body	TV Antenna Module																																																										
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
E	2005	ALL	Body	Vehicle Theft Deterrent																																																										
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																										
E	2006	ALL	Chassis	Electronic Suspension Control																																																										
E	2006	ALL	Chassis	Tire Pressure Monitor																																																										
E	2006	ALL	Chassis	VES																																																										
E	2006	ALL	Body	Amplifier (Bose)																																																										
E	2006	ALL	Body	Amplifier (Delco)																																																										
E	2006	ALL	Body	Climate Control Panel																																																										
E	2006	ALL	Body	Dash Integration Module																																																										
E	2006	ALL	Body	Disc Player and Video Display																																																										
E	2006	ALL	Body	Driver Door Switch																																																										
E	2006	ALL	Body	Driver Door Module																																																										
E	2006	ALL	Body	Passenger Door Module																																																										
E	2006	ALL	Body	Left Rear Door Module																																																										
E	2006	ALL	Body	Right Rear Door Module																																																										
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2006	ALL	Body	Instrument Panel Cluster																																																										
E	2006	ALL	Body	Lift Gate Module																																																										
E	2006	ALL	Body	Memory Seat Module																																																										
E	2006	ALL	Body	Personalization																																																										
E	2006	ALL	Body	Base Radio																																																										
E	2006	ALL	Body	Navigation Radio																																																										
E	2006	ALL	Body	Rear Integration Module																																																										
E	2006	ALL	Body	Rear Seat Module																																																										
E	2006	ALL	Body	Remote Function Actuation																																																										
E	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
E	2006	ALL	Body	Vehicle Theft Deterrent																																																										
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module				V																																																						
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V				V																																																					
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module		V																																																								
E	2007	ALL	Chassis	Electronic Brake Control Module						V																																																				

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
E	2007	ALL	Chassis	Electronic Suspension Control																																																										
E	2007	ALL	Body	Amplifier (Bose)																																																											
E	2007	ALL	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																
E	2007	ALL	Body	Body Control Module (aux.)																																																											
E	2007	ALL	Body	Digital Radio Receiver																																																											
E	2007	ALL	Body	Driver Door Switch																																																											
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																											
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																											
E	2007	ALL	Body	HVAC Control Module																												V	V																															
E	2007	ALL	Body	Instrument Panel Cluster																																																											
E	2007	ALL	Body	Lift Gate Module																																																											
E	2007	ALL	Body	Memory Seat Module																														V	V	V	V				V																						
E	2007	ALL	Body	Park Assist Module																																						V	V	V																		
E	2007	ALL	Body	Passenger Door Switch																																																											
E	2007	ALL	Body	Passenger Presence System																																									V	V																	
E	2007	ALL	Body	Radio																																																											
E	2007	ALL	Body	Rear HVAC/RSA																																																												
E	2007	ALL	Body	Rear Seat Module																																																												
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																												
E	2007	ALL	Body	Rollover Sensor																																																												
E	2007	ALL	Body	Supplemental Inflatable Restraint																																									V										V							
E	2007	ALL	Body	Theft Deterrent Module																																																											
E	2007	ALL	Body	TV Antenna Module																																																												
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module				V																																																								
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V																																																											
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module		V																																																										
E	2008	ALL	Chassis	Electronic Brake Control Module						V																																																						
E	2008	ALL	Chassis	Electronic Suspension Control																																																												
E	2008	ALL	Body	Amplifier (Bose)																																																												
E	2008	ALL	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																																
E	2008	ALL	Body	Body Control Module (aux.)																																																												
E	2008	ALL	Body	Digital Radio Receiver																																																												
E	2008	ALL	Body	Driver Door Switch																																																												
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																												
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																												
E	2008	ALL	Body	HVAC Control Module																												V	V																															
E	2008	ALL	Body	Instrument Panel Cluster																																																												
E	2008	ALL	Body	Lift Gate Module																																																												
E	2008	ALL	Body	Memory Seat Module																														V	V	V	V				V																						
E	2008	ALL	Body	Park Assist Module																																						V	V	V																		
E	2008	ALL	Body	Passenger Door Switch																																																											
E	2008	ALL	Body	Passenger Presence System																																									V	V																	
E	2008	ALL	Body	Radio																																																											
E	2008	ALL	Body	Rear HVAC/RSA																																																												
E	2008	ALL	Body	Rear Seat Module																																																												
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																												
E	2008	ALL	Body	Rollover Sensor																																																												
E	2008	ALL	Body	Supplemental Inflatable Restraint																																									V										V							
E	2008	ALL	Body	Theft Deterrent Module																																																												
E	2008	ALL	Body	TV Antenna Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module				V																																																						
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module	V																																																										
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module		V																																																									
E	2009	ALL	Chassis	Electronic Brake Control Module						V																																																					
E	2009	ALL	Chassis	Electronic Suspension Control																																																											
E	2009	ALL	Body	Amplifier (Bose)																																																											
E	2009	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
E	2009	ALL	Body	Body Control Module (aux.)																																																											
E	2009	ALL	Body	Digital Radio Receiver																																																											
E	2009	ALL	Body	Driver Door Switch																																																											
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																											
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																											
E	2009	ALL	Body	HVAC Control Module																												V	V																															
E	2009	ALL	Body	Instrument Panel Cluster																																																											
E	2009	ALL	Body	Lift Gate Module																																																											
E	2009	ALL	Body	Memory Seat Module																														V	V	V	V				V																							
E	2009	ALL	Body	Park Assist Module																																							V	V	V																		
E	2009	ALL	Body	Passenger Door Switch																																																											
E	2009	ALL	Body	Passenger Presence System																																										V	V																	
E	2009	ALL	Body	Radio																																																											
E	2009	ALL	Body	Rear HVAC/RSA																																																											
E	2009	ALL	Body	Rear Seat Module																																																											
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																											
E	2009	ALL	Body	Rollover Sensor																																																											
E	2009	ALL	Body	Supplemental Inflatable Restraint																																										V									V							
E	2009	ALL	Body	Theft Deterrent Module																																																											
E	2009	ALL	Body	TV Antenna Module																																																											
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																											
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																											
K	2004	ALL	Chassis	ESC																																																										
K	2004	ALL	Chassis	Rear Wheel Steering																																																											
K	2004	ALL	Chassis	Tire Pressure Monitor																																																											
K	2004	ALL	Chassis	VSES																																																										
K	2004	ALL	Body	Amplifier (Bose)																																																											
K	2004	ALL	Body	Body Control Module																																																											
K	2004	ALL	Body	CD Changer																																																											
K	2004	ALL	Body	Chime																																																											
K	2004	ALL	Body	Driver Door Module																																																											
K	2004	ALL	Body	Driver Seat Module																																																											
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2004	ALL	Body	Instrument Panel Cluster																																																											
K	2004	ALL	Body	OnStar																																																											
K	2004	ALL	Body	Passenger Door Module																																																											
K	2004	ALL	Body	Passenger Presence System																																																											
K	2004	ALL	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2004	ALL	Body	Uplevel Radio																																																									
K	2004	ALL	Body	Navigation Radio																																																									
K	2004	ALL	Body	Rear Aux. Climate Module																																																									
K	2004	ALL	Body	Rear HVAC																																																									
K	2004	ALL	Body	Rear Seat Audio																																																									
K	2004	ALL	Body	Rear Seat Entertainment																																																									
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																									
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																									
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2005	ALL	Chassis	ESC																																																								
K	2005	ALL	Chassis	Rear Wheel Steering																																																									
K	2005	ALL	Chassis	Tire Pressure Monitor																																																									
K	2005	ALL	Chassis	VSES																																																									
K	2005	ALL	Body	Amplifier (Bose)																																																									
K	2005	ALL	Body	Body Control Module																																																									
K	2005	ALL	Body	CD Changer																																																									
K	2005	ALL	Body	Chime																																																									
K	2005	ALL	Body	Disc Player and Video Display																																																									
K	2005	ALL	Body	Driver Door Module																																																									
K	2005	ALL	Body	Driver Seat Module																																																									
K	2005	ALL	Body	Generator Battery Control Module																																																									
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																									
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2005	ALL	Body	Instrument Panel Cluster																																																									
K	2005	ALL	Body	Passenger Door Module																																																									
K	2005	ALL	Body	Passenger Presence System																																																									
K	2005	ALL	Body	Base Radio																																																									
K	2005	ALL	Body	Uplevel Radio																																																									
K	2005	ALL	Body	Navigation Radio																																																									
K	2005	ALL	Body	Rear Aux. Climate Module																																																									
K	2005	ALL	Body	Rear HVAC																																																									
K	2005	ALL	Body	Rear Seat Audio																																																									
K	2005	ALL	Body	Remote Function Actuation																																																									
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																									
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																									
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2006	ALL	Chassis	ESC																																																								
K	2006	ALL	Chassis	Tire Pressure Monitor																																																									
K	2006	ALL	Chassis	VSES																																																									
K	2006	ALL	Body	Amplifier (Bose)																																																									
K	2006	ALL	Body	Body Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2006	ALL	Body	CD Changer																																																										
K	2006	ALL	Body	Chime																																																										
K	2006	ALL	Body	Disc Player and Video Display																																																										
K	2006	ALL	Body	Driver Door Module																																																										
K	2006	ALL	Body	Driver Seat Module																																																										
K	2006	ALL	Body	Generator Battery Control Module																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2006	ALL	Body	Instrument Panel Cluster																																																										
K	2006	ALL	Body	Passenger Door Module																																																										
K	2006	ALL	Body	Passenger Presence System																																																										
K	2006	ALL	Body	Base Radio																																																										
K	2006	ALL	Body	Uplevel Radio																																																										
K	2006	ALL	Body	Navigation Radio																																																										
K	2006	ALL	Body	Rear Aux. Climate Module																																																										
K	2006	ALL	Body	Rear HVAC																																																										
K	2006	ALL	Body	Rear Seat Audio																																																										
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module				V																																																						
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																								
K	2007	ALL	Chassis	Electronic Brake Control Module																																																										
K	2007	ALL	Chassis	Electronic Suspension Control																																																										
K	2007	ALL	Body	Amplifier (Bose)																																																										
K	2007	ALL	Body	Assist Step Controller																																																										
K	2007	ALL	Body	Body Control Module														V	V	V	V	V	V	V		V	V			V																																
K	2007	ALL	Body	Body Control Module (aux.)																																																										
K	2007	ALL	Body	Digital Radio Receiver																																																										
K	2007	ALL	Body	Driver Door Switch																																																										
K	2007	ALL	Body	HVAC Control Module																											V	V																														
K	2007	ALL	Body	Inside Rear View Mirror Module																																																										
K	2007	ALL	Body	Instrument Panel Cluster																																																										
K	2007	ALL	Body	Lift Gate Module																																																										
K	2007	ALL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2007	ALL	Body	Park Assist Module																																							V	V	V																	
K	2007	ALL	Body	Passenger Door Switch																																																										
K	2007	ALL	Body	Passenger Presence System																																										V																
K	2007	ALL	Body	Radio																																																										
K	2007	ALL	Body	Rear Heated Seat Module																																	V				V																					
K	2007	ALL	Body	Rear HVAC/RSA																																																										
K	2007	ALL	Body	Rollover Sensor																																																										
K	2007	ALL	Body	Supplemental Inflatable Restraint																																										V									V							
K	2007	ALL	Body	Theft Deterrent Module																																																										
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module	V			V																																																						
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																								
K	2008	ALL	Chassis	Electronic Brake Control Module																																																										
K	2008	ALL	Chassis	Electronic Suspension Control																																																										
K	2008	ALL	Chassis	Trailer Brake Control Module																																																										
K	2008	ALL	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2008	ALL	Body	Assist Step Controller																																																										
K	2008	ALL	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																															
K	2008	ALL	Body	Body Control Module (aux.)																																																										
K	2008	ALL	Body	Digital Radio Receiver																																																										
K	2008	ALL	Body	Driver Door Switch																																																										
K	2008	ALL	Body	HVAC Control Module																												V	V																														
K	2008	ALL	Body	Inside Rear View Mirror Module																																																										
K	2008	ALL	Body	Instrument Panel Cluster																																																										
K	2008	ALL	Body	Lift Gate Module																																																										
K	2008	ALL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2008	ALL	Body	Park Assist Module																																							V	V	V																	
K	2008	ALL	Body	Passenger Door Switch																																																										
K	2008	ALL	Body	Passenger Presence System																																										V																
K	2008	ALL	Body	Radio																																																										
K	2008	ALL	Body	Rear Heated Seat Module																																	V				V																					
K	2008	ALL	Body	Rear HVAC/RSA																																																										
K	2008	ALL	Body	Rollover Sensor																																																										
K	2008	ALL	Body	Supplemental Inflatable Restraint																																										V									V							
K	2008	ALL	Body	Theft Deterrent Module																																																										
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																							
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																									
K	2009	ALL	Chassis	Electronic Brake Control Module																																																											
K	2009	ALL	Chassis	Electronic Suspension Control																																																											
K	2009	ALL	Chassis	Trailer Brake Control Module																																																											
K	2009	ALL	Body	Amplifier (Bose)																																																											
K	2009	ALL	Body	Assist Step Controller																																																											
K	2009	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
K	2009	ALL	Body	Body Control Module (aux.)																																																											
K	2009	ALL	Body	Digital Radio Receiver																																																											
K	2009	ALL	Body	Driver Door Switch																																																											
K	2009	ALL	Body	HVAC Control Module																												V	V																														
K	2009	ALL	Body	Inside Rear View Mirror Module																																																											
K	2009	ALL	Body	Instrument Panel Cluster																																																											
K	2009	ALL	Body	Left Side Object Detection Module																																								V					V													
K	2009	ALL	Body	Lift Gate Module																																																											
K	2009	ALL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																					
K	2009	ALL	Body	Park Assist Module																																							V	V	V																	
K	2009	ALL	Body	Passenger Door Switch																																																										
K	2009	ALL	Body	Passenger Presence System																																										V																
K	2009	ALL	Body	Radio																																																										
K	2009	ALL	Body	Rear Heated Seat Module																																	V				V																					
K	2009	ALL	Body	Rear HVAC/RSA																																																											
K	2009	ALL	Body	Right Side Object Detection Module																																								V					V													
K	2009	ALL	Body	Rollover Sensor																																																											
K	2009	ALL	Body	Supplemental Inflatable Restraint																																										V									V							
K	2009	ALL	Body	Theft Deterrent Module																																																											
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																							
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																									
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																							

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
K	2010	ALL	Chassis	Electronic Brake Control Module																																																										
K	2010	ALL	Chassis	Electronic Suspension Control																																																										
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	ALL	Body	Amplifier (Bose)																																																										
K	2010	ALL	Body	Assist Step Controller																																																										
K	2010	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2010	ALL	Body	Body Control Module (aux.)																																																										
K	2010	ALL	Body	Digital Radio Receiver																																																										
K	2010	ALL	Body	Driver Door Switch																																																										
K	2010	ALL	Body	HVAC Control Module																												V	V																													
K	2010	ALL	Body	Inside Rear View Mirror Module																																																										
K	2010	ALL	Body	Instrument Panel Cluster																																																										
K	2010	ALL	Body	Left Side Object Detection Module																																								V					V													
K	2010	ALL	Body	Lift Gate Module																																																										
K	2010	ALL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				
K	2010	ALL	Body	Park Assist Module																																							V	V	V																	
K	2010	ALL	Body	Passenger Door Switch																																																										
K	2010	ALL	Body	Passenger Presence System																																										V																
K	2010	ALL	Body	Radio																																																										
K	2010	ALL	Body	Rear Heated Seat Module																																		V				V																				
K	2010	ALL	Body	Rear HVAC/RSA																																																										
K	2010	ALL	Body	Right Side Object Detection Module																																								V					V													
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2010	ALL	Body	Theft Deterrent Module																																																										
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																										
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																										
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																										
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2010	SRX	Chassis	Electronic Brake Control Module																																																										
N	2010	SRX	Chassis	Parking Brake Control Module																																																										
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2010	SRX	Chassis	Suspension Control Module																																																										
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2010	SRX	Body	Passenger Presence Module																																																										
N	2010	SRX	Body	Instrument Cluster																																																										
N	2010	SRX	Body	Headlamp Control Module																																																										
N	2010	SRX	Body	Trailer Interface Control Module																																																										
N	2010	SRX	Body	Radio																																																										
N	2010	SRX	Body	Rear Audio Control Module																																																										
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2010	SRX	Body	Multimedia Player Interface Module																																																										
N	2010	SRX	Body	Mobile Telephone Control Module																																																										
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2010	SRX	Body	Liftgate Control Module																																																										
N	2010	SRX	Body	Seat Memory Control Module																																																										
N	2010	SRX	Body	Front Seat Heating Control Module																																																										
N	2010	SRX	Body	Rear Seat Heating Control Module																																																										
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2010	SRX	Body	Parking Assist Control Module																																																										
N	2010	SRX	Body	Steering Column Lock Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2011	SRX	Chassis	Electronic Brake Control Module																																																										
N	2011	SRX	Chassis	Parking Brake Control Module																																																										
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2011	SRX	Chassis	Suspension Control Module																																																										
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2011	SRX	Body	Passenger Presence Module																																																										
N	2011	SRX	Body	Instrument Cluster																																																										
N	2011	SRX	Body	Headlamp Control Module																																																										
N	2011	SRX	Body	Trailer Interface Control Module																																																										
N	2011	SRX	Body	Radio																																																										
N	2011	SRX	Body	Rear Audio Control Module																																																										
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2011	SRX	Body	Multimedia Player Interface Module																																																										
N	2011	SRX	Body	Mobile Telephone Control Module																																																										
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2011	SRX	Body	Liftgate Control Module																																																										
N	2011	SRX	Body	Seat Memory Control Module																																																										
N	2011	SRX	Body	Front Seat Heating Control Module																																																										
N	2011	SRX	Body	Rear Seat Heating Control Module																																																										
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2011	SRX	Body	Parking Assist Control Module																																																										
N	2011	SRX	Body	Steering Column Lock Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																										
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2012	SRX	Chassis	Electronic Brake Control Module																																																										
N	2012	SRX	Chassis	Parking Brake Control Module																																																										
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2012	SRX	Chassis	Suspension Control Module																																																										
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2012	SRX	Body	Passenger Presence Module																																																										
N	2012	SRX	Body	Instrument Cluster																																																										
N	2012	SRX	Body	Headlamp Control Module																																																										
N	2012	SRX	Body	Trailer Interface Control Module																																																										
N	2012	SRX	Body	Radio																																																										
N	2012	SRX	Body	Rear Audio Control Module																																																										
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2012	SRX	Body	Multimedia Player Interface Module																																																										
N	2012	SRX	Body	Mobile Telephone Control Module																																																										
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2012	SRX	Body	Liftgate Control Module																																																										
N	2012	SRX	Body	Seat Memory Control Module																																																										
N	2012	SRX	Body	Front Seat Heating Control Module																																																										
N	2012	SRX	Body	Rear Seat Heating Control Module																																																										
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2012	SRX	Body	Parking Assist Control Module																																																										
N	2012	SRX	Body	Steering Column Lock Control Module																																																										
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2013	SRX	Chassis	Electronic Brake Control Module																																																										
N	2013	SRX	Chassis	Parking Brake Control Module																																																										
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2013	SRX	Chassis	Suspension Control Module																																																										
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2013	SRX	Body	Passenger Presence Module																																																										
N	2013	SRX	Body	Instrument Cluster																																																										
N	2013	SRX	Body	Radio/HVAC Control																																																										
N	2013	SRX	Body	Active Safety Control Module																																																										
N	2013	SRX	Body	Headlamp Control Module																																																										
N	2013	SRX	Body	Trailer Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
N	2013	SRX	Body	Radio																																																										
N	2013	SRX	Body	Amplifier																																																										
N	2013	SRX	Body	Media Disc Player																																																										
N	2013	SRX	Body	Human Machine Interface Control Module																																																											
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																																											
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
N	2013	SRX	Body	Liftgate Control Module																																																											
N	2013	SRX	Body	Seat Memory Control Module																																																											
N	2013	SRX	Body	Rear Seat Heating Control Module																																																											
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2013	SRX	Body	Right Side Object Detection Control Module																																																											
N	2013	SRX	Body	Left Side Object Detection Control Module																																																											
N	2013	SRX	Body	Parking Assist Control Module																																																											
N	2013	SRX	Body	Frontview Camera Module																																																											
N	2013	SRX	Body	Steering Column Lock Control Module																																																											
N	2013	SRX	Body	Long Range Radar Sensor Module																																																											
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																											
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2014	SRX	Chassis	Electronic Brake Control Module																																																											
N	2014	SRX	Chassis	Parking Brake Control Module																																																											
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2014	SRX	Chassis	Suspension Control Module																																																											
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2014	SRX	Body	Passenger Presence Module																																																											
N	2014	SRX	Body	Instrument Cluster																																																											
N	2014	SRX	Body	Radio/HVAC Control																																																											
N	2014	SRX	Body	Active Safety Control Module																																																											
N	2014	SRX	Body	Headlamp Control Module																																																											
N	2014	SRX	Body	Trailer Interface Control Module																																																											
N	2014	SRX	Body	Radio																																																											
N	2014	SRX	Body	Amplifier																																																											
N	2014	SRX	Body	Media Disc Player																																																											
N	2014	SRX	Body	Human Machine Interface Control Module																																																											
N	2014	SRX	Body	Navigation Control Module																																																											
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																											
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
N	2014	SRX	Body	Liftgate Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2014	SRX	Body	Rear Seat Heating Control Module																																																											
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2014	SRX	Body	Right Side Object Detection Control Module																																																										
N	2014	SRX	Body	Left Side Object Detection Control Module																																																										
N	2014	SRX	Body	Parking Assist Control Module																																																										
N	2014	SRX	Body	Frontview Camera Module																																																										
N	2014	SRX	Body	Steering Column Lock Control Module																																																										
N	2014	SRX	Body	Long Range Radar Sensor Module																																																										
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																										
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2015	SRX	Chassis	Electronic Brake Control Module																																																										
N	2015	SRX	Chassis	Parking Brake Control Module																																																										
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2015	SRX	Chassis	Suspension Control Module																																																										
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2015	SRX	Body	Passenger Presence Module																																																										
N	2015	SRX	Body	Instrument Cluster																																																										
N	2015	SRX	Body	Radio/HVAC Control																																																										
N	2015	SRX	Body	Active Safety Control Module																																																										
N	2015	SRX	Body	Headlamp Control Module																																																										
N	2015	SRX	Body	Trailer Interface Control Module																																																										
N	2015	SRX	Body	Radio																																																										
N	2015	SRX	Body	Amplifier																																																										
N	2015	SRX	Body	Rear Audio Control Module																																																										
N	2015	SRX	Body	Media Disc Player																																																										
N	2015	SRX	Body	Human Machine Interface Control Module																																																										
N	2015	SRX	Body	Navigation Control Module																																																										
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																										
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2015	SRX	Body	Liftgate Control Module																																																										
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2015	SRX	Body	Rear Seat Heating Control Module																																																										
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2015	SRX	Body	Right Side Object Detection Control Module																																																										
N	2015	SRX	Body	Left Side Object Detection Control Module																																																										
N	2015	SRX	Body	Parking Assist Control Module																																																										
N	2015	SRX	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
N	2015	SRX	Body	Steering Column Lock Control Module																																																										
N	2015	SRX	Body	Long Range Radar Sensor Module																																																											
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																											
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2016	SRX	Chassis	Electronic Brake Control Module																																																											
N	2016	SRX	Chassis	Parking Brake Control Module																																																											
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2016	SRX	Chassis	Suspension Control Module																																																											
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2016	SRX	Body	Passenger Presence Module																																																											
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																																											
N	2016	SRX	Body	Radio/HVAC Control																																																											
N	2016	SRX	Body	Active Safety Control Module																																																											
N	2016	SRX	Body	Headlamp Control Module																																																											
N	2016	SRX	Body	Trailer Interface Control Module																																																											
N	2016	SRX	Body	Radio																																																											
N	2016	SRX	Body	Amplifier																																																										
N	2016	SRX	Body	Rear Audio Control Module																																																											
N	2016	SRX	Body	Media Disc Player																																																											
N	2016	SRX	Body	Human Machine Interface Control Module																																																											
N	2016	SRX	Body	Navigation Control Module																																																											
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																											
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
N	2016	SRX	Body	Liftgate Control Module																																																											
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																											
N	2016	SRX	Body	Rear Seat Heating Control Module																																																											
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2016	SRX	Body	Right Side Object Detection Control Module																																																											
N	2016	SRX	Body	Left Side Object Detection Control Module																																																											
N	2016	SRX	Body	Parking Assist Control Module																																																											
N	2016	SRX	Body	Frontview Camera Module																																																											
N	2016	SRX	Body	Steering Column Lock Control Module																																																											
N	2016	SRX	Body	Long Range Radar Sensor Module																																																											
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																											
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																							
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																								
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																						
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
3	2011	ALL	Chassis	Electronic Brake Control Module																																																											
3	2011	ALL	Chassis	Electronic Suspension Control																																																										
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2011	ALL	Body	Amplifier (Bose)																																																										
3	2011	ALL	Body	Assist Step Controller																																																										
3	2011	ALL	Body	Body Control Module														V	V	V	V	V		V		V	V			V																																
3	2011	ALL	Body	Body Control Module (aux.)																																																										
3	2011	ALL	Body	Digital Radio Receiver																																																										
3	2011	ALL	Body	Driver Door Switch																																																										
3	2011	ALL	Body	HVAC Control Module																											V	V																															
3	2011	ALL	Body	Inside Rear View Mirror Module																																																										
3	2011	ALL	Body	Instrument Panel Cluster																																																										
3	2011	ALL	Body	Left Side Object Detection Module																																							V					V														
3	2011	ALL	Body	Lift Gate Module																																																										
3	2011	ALL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				
3	2011	ALL	Body	Park Assist Module																																							V	V	V																
3	2011	ALL	Body	Passenger Door Switch																																																										
3	2011	ALL	Body	Passenger Presence System																																										V															
3	2011	ALL	Body	Radio																																																										
3	2011	ALL	Body	Rear Heated Seat Module																																	V			V																					
3	2011	ALL	Body	Rear HVAC/RSA																																																										
3	2011	ALL	Body	Right Side Object Detection Module																																							V					V														
3	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
3	2011	ALL	Body	Theft Deterrent Module																																																										
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																						
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																									
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																							
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																									
3	2012	ALL	Chassis	Electronic Brake Control Module														V																																													
3	2012	ALL	Chassis	Electronic Suspension Control																																																											
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																											
3	2012	ALL	Body	Amplifier (Bose)																																																										
3	2012	ALL	Body	Assist Step Controller																																																										
3	2012	ALL	Body	Body Control Module														V	V	V	V	V		V		V	V			V																																
3	2012	ALL	Body	Body Control Module (aux.)																																																										
3	2012	ALL	Body	Driver Door Switch																																																										
3	2012	ALL	Body	HVAC Control Module																											V	V																															
3	2012	ALL	Body	Inside Rear View Mirror Module																																																										
3	2012	ALL	Body	Instrument Panel Cluster																																																										
3	2012	ALL	Body	Left Side Object Detection Module																																							V					V														
3	2012	ALL	Body	Lift Gate Module																																																										
3	2012	ALL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				
3	2012	ALL	Body	Park Assist Module																																							V	V	V																
3	2012	ALL	Body	Passenger Door Switch																																																										
3	2012	ALL	Body	Passenger Presence System																																										V															

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
3	2012	ALL	Body	Radio																																																									
3	2012	ALL	Body	Rear Heated Seat Module																																		V				V																			
3	2012	ALL	Body	Rear HVAC/RSA																																																									
3	2012	ALL	Body	Right Side Object Detection Module																																									V				V												
3	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
3	2012	ALL	Body	Theft Deterrent Module																																																									
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																					
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																							
3	2013	ALL	Chassis	Electronic Brake Control Module														V																																											
3	2013	ALL	Chassis	Electronic Suspension Control																																																									
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																									
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																									
3	2013	ALL	Body	Amplifier (Bose)																																																									
3	2013	ALL	Body	Assist Step Controller																																																									
3	2013	ALL	Body	Body Control Module														V	V	V	V	V		V		V	V			V																															
3	2013	ALL	Body	Body Control Module (aux.)																																																									
3	2013	ALL	Body	Driver Door Switch																																																									
3	2013	ALL	Body	HVAC Control Module																												V	V																												
3	2013	ALL	Body	Inside Rear View Mirror Module																																																									
3	2013	ALL	Body	Instrument Panel Cluster																																																									
3	2013	ALL	Body	Left Side Object Detection Module																																									V				V												
3	2013	ALL	Body	Lift Gate Module																																																									
3	2013	ALL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																			
3	2013	ALL	Body	Park Assist Module																																							V	V	V																
3	2013	ALL	Body	Passenger Door Switch																																																									
3	2013	ALL	Body	Passenger Presence System																																											V														
3	2013	ALL	Body	Radio																																																									
3	2013	ALL	Body	Rear Heated Seat Module																																		V				V																			
3	2013	ALL	Body	Rear HVAC/RSA																																																									
3	2013	ALL	Body	Right Side Object Detection Module																																									V				V												
3	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
3	2013	ALL	Body	Theft Deterrent Module																																																									
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																									
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																									
3	2014	Escalade	Chassis	Suspension Control Module																																																									
3	2014	Escalade	Body	Body Control Module																																																									
3	2014	Escalade	Body	Auxiliary Body Control Module																																																									
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
3	2014	Escalade	Body	Passenger Presence Module																																																									
3	2014	Escalade	Body	Instrument Cluster																																																									
3	2014	Escalade	Body	Radio																																																									
3	2014	Escalade	Body	Amplifier																																																									
3	2014	Escalade	Body	Rear Audio Control Module																																																									
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																									
3	2014	Escalade	Body	Personal Audio Link Control Module																																																									
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																									
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
3	2014	Escalade	Body	HVAC Control Module																																																									
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																									
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																									
3	2014	Escalade	Body	Liftgate Control Module																																																									
3	2014	Escalade	Body	Seat Memory Control Module																																																									
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																									
3	2014	Escalade	Body	Assist Step Control Module																																																									
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																									
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																									
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																									
3	2014	Escalade	Body	Parking Assist Control Module																																																									
3	2014	Escalade	Body	Theft Deterrent Module																																																									
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																									
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																									
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																									
3	2014	Escalade ESV	Body	Body Control Module																																																									
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																									
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
3	2014	Escalade ESV	Body	Passenger Presence Module																																																									
3	2014	Escalade ESV	Body	Instrument Cluster																																																									
3	2014	Escalade ESV	Body	Radio																																																									
3	2014	Escalade ESV	Body	Amplifier																																																									
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																									
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																									
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																									
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																									
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																									
3	2014	Escalade ESV	Body	HVAC Control Module																																																									
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																									
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																									
3	2014	Escalade ESV	Body	Liftgate Control Module																																																									
3	2014	Escalade ESV	Body	Seat Memory Control Module																																																									
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																									
3	2014	Escalade ESV	Body	Assist Step Control Module																																																									
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																									
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																									
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																									
3	2014	Escalade ESV	Body	Parking Assist Control Module																																																									
3	2014	Escalade ESV	Body	Theft Deterrent Module																																																									
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																									
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																									
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																										
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																										
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																										
3	2015	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2015	Escalade	Chassis	Parking Brake Control Module																																																										
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2015	Escalade	Chassis	Power Steering Control Module																																																										
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2015	Escalade	Chassis	Suspension Control Module																																																										
3	2015	Escalade	Body	Body Control Module																																																										
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2015	Escalade	Body	Passenger Presence Module																																																										
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2015	Escalade	Body	Instrument Cluster																																																										
3	2015	Escalade	Body	Radio/HVAC Control																																																										
3	2015	Escalade	Body	Active Safety Control Module																																																										
3	2015	Escalade	Body	Video Processing Control Module																																																										
3	2015	Escalade	Body	Radio																																																										
3	2015	Escalade	Body	Amplifier																																																										
3	2015	Escalade	Body	Media Disc Player																																																										
3	2015	Escalade	Body	Human Machine Interface Control Module																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2015	Escalade	Body	HVAC Control Module																																																										
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																										
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																										
3	2015	Escalade	Body	Keyless Entry Control Module																																																										
3	2015	Escalade	Body	Assist Step Control Module																																																										
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																										
3	2015	Escalade	Body	Parking Assist Control Module																																																										
3	2015	Escalade	Body	Frontview Camera Module																																																										
3	2015	Escalade	Body	Steering Column Lock Control Module																																																										
3	2015	Escalade	Body	Battery Energy Control Module																																																										
3	2015	Escalade	Body	Long Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																										
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																																										
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2015	Escalade ESV	Body	Body Control Module																																																										
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2015	Escalade ESV	Body	Passenger Presence Module																																																										
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2015	Escalade ESV	Body	Instrument Cluster																																																										
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																										
3	2015	Escalade ESV	Body	Active Safety Control Module																																																										
3	2015	Escalade ESV	Body	Video Processing Control Module																																																										
3	2015	Escalade ESV	Body	Radio																																																										
3	2015	Escalade ESV	Body	Amplifier																																																										
3	2015	Escalade ESV	Body	Media Disc Player																																																										
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2015	Escalade ESV	Body	HVAC Control Module																																																										
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																										
3	2015	Escalade ESV	Body	Assist Step Control Module																																																										
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2015	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2015	Escalade ESV	Body	Frontview Camera Module																																																										
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																										
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2016	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2016	Escalade	Chassis	Parking Brake Control Module																																																										
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2016	Escalade	Chassis	Power Steering Control Module																																																										
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2016	Escalade	Chassis	Suspension Control Module																																																										
3	2016	Escalade	Body	Body Control Module																																																										
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
3	2016	Escalade	Body	Passenger Presence Module																																																										
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2016	Escalade	Body	Instrument Cluster																																																										
3	2016	Escalade	Body	Radio/HVAC Control																																																										
3	2016	Escalade	Body	Active Safety Control Module																																																										
3	2016	Escalade	Body	Video Processing Control Module																																																										
3	2016	Escalade	Body	Radio																																																										
3	2016	Escalade	Body	Amplifier																																																										
3	2016	Escalade	Body	Media Disc Player																																																										
3	2016	Escalade	Body	Human Machine Interface Control Module																																																										
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																																										
3	2016	Escalade	Body	HVAC Control Module																																																										
3	2016	Escalade	Body	Liftgate Control Module																																																										
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																										
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																										
3	2016	Escalade	Body	Keyless Entry Control Module																																																										
3	2016	Escalade	Body	Assist Step Control Module																																																										
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																										
3	2016	Escalade	Body	Parking Assist Control Module																																																										
3	2016	Escalade	Body	Frontview Camera Module																																																										
3	2016	Escalade	Body	Steering Column Lock Control Module																																																										
3	2016	Escalade	Body	Long Range Radar Sensor Module																																																										
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																										
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																																										
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2016	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2016	Escalade ESV	Body	Body Control Module																																																										
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2016	Escalade ESV	Body	Passenger Presence Module																																																										
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2016	Escalade ESV	Body	Instrument Cluster																																																										
3	2016	Escalade ESV	Body	Radio Control																																																										
3	2016	Escalade ESV	Body	HVAC Control																																																										
3	2016	Escalade ESV	Body	Active Safety Control Module																																																										
3	2016	Escalade ESV	Body	Video Processing Control Module																																																										
3	2016	Escalade ESV	Body	Radio																																																										
3	2016	Escalade ESV	Body	Amplifier																																																										
3	2016	Escalade ESV	Body	Media Disc Player																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																										
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																										
3	2016	Escalade ESV	Body	HVAC Control Module																																																										
3	2016	Escalade ESV	Body	Liftgate Control Module																																																										
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																										
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																										
3	2016	Escalade ESV	Body	Assist Step Control Module																																																										
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2016	Escalade ESV	Body	Frontview Camera Module																																																										
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																										
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																						
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																								
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																						
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
4	2011	ALL	Chassis	Electronic Brake Control Module																																																										
4	2011	ALL	Chassis	Electronic Suspension Control																																																										
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																										
4	2011	ALL	Body	Amplifier (Bose)																																																										
4	2011	ALL	Body	Assist Step Controller																																																										
4	2011	ALL	Body	Body Control Module														V	V	V	V	V		V		V	V			V																																
4	2011	ALL	Body	Body Control Module (aux.)																																																										
4	2011	ALL	Body	Driver Door Switch																																																										
4	2011	ALL	Body	HVAC Control Module																												V	V																													
4	2011	ALL	Body	Inside Rear View Mirror Module																																																										
4	2011	ALL	Body	Instrument Panel Cluster																																																										
4	2011	ALL	Body	Left Side Object Detection Module																																							V				V															
4	2011	ALL	Body	Lift Gate Module																																																										
4	2011	ALL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				
4	2011	ALL	Body	Park Assist Module																																						V	V	V																		
4	2011	ALL	Body	Passenger Door Switch																																																										
4	2011	ALL	Body	Passenger Presence System																																									V																	
4	2011	ALL	Body	Radio																																																										
4	2011	ALL	Body	Rear Heated Seat Module																																	V				V																					
4	2011	ALL	Body	Rear HVAC/RSA																																																										
4	2011	ALL	Body	Right Side Object Detection Module																																							V				V															
4	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
4	2011	ALL	Body	Theft Deterrent Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																						
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																								
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																						
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
4	2012	ALL	Chassis	Electronic Brake Control Module														V																																												
4	2012	ALL	Chassis	Electronic Suspension Control																																																											
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2012	ALL	Body	Amplifier (Bose)																																																											
4	2012	ALL	Body	Assist Step Controller																																																											
4	2012	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
4	2012	ALL	Body	Body Control Module (aux.)																																																											
4	2012	ALL	Body	Driver Door Switch																																																											
4	2012	ALL	Body	HVAC Control Module																												V	V																															
4	2012	ALL	Body	Inside Rear View Mirror Module																																																											
4	2012	ALL	Body	Instrument Panel Cluster																																																											
4	2012	ALL	Body	Left Side Object Detection Module																																								V					V													
4	2012	ALL	Body	Lift Gate Module																																																											
4	2012	ALL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																					
4	2012	ALL	Body	Park Assist Module																																							V	V	V																	
4	2012	ALL	Body	Passenger Door Switch																																																											
4	2012	ALL	Body	Passenger Presence System																																										V																	
4	2012	ALL	Body	Radio																																																											
4	2012	ALL	Body	Rear Heated Seat Module																																	V				V																						
4	2012	ALL	Body	Rear HVAC/RSA																																																											
4	2012	ALL	Body	Right Side Object Detection Module																																								V					V													
4	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
4	2012	ALL	Body	Theft Deterrent Module																																																												
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																								
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																										
4	2013	ALL	Chassis	Electronic Brake Control Module														V																																													
4	2013	ALL	Chassis	Electronic Suspension Control																																																												
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																												
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																												
4	2013	ALL	Body	Amplifier (Bose)																																																												
4	2013	ALL	Body	Assist Step Controller																																																												
4	2013	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
4	2013	ALL	Body	Body Control Module (aux.)																																																												
4	2013	ALL	Body	Driver Door Switch																																																												
4	2013	ALL	Body	HVAC Control Module																												V	V																															
4	2013	ALL	Body	Inside Rear View Mirror Module																																																												
4	2013	ALL	Body	Instrument Panel Cluster																																																												
4	2013	ALL	Body	Left Side Object Detection Module																																								V					V													
4	2013	ALL	Body	Lift Gate Module																																																												
4	2013	ALL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																					
4	2013	ALL	Body	Park Assist Module																																							V	V	V																	
4	2013	ALL	Body	Passenger Door Switch																																																											
4	2013	ALL	Body	Passenger Presence System																																										V																	
4	2013	ALL	Body	Radio																																																											
4	2013	ALL	Body	Rear Heated Seat Module																																	V				V																						
4	2013	ALL	Body	Rear HVAC/RSA																																																												
4	2013	ALL	Body	Right Side Object Detection Module																																								V					V													
4	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
4	2013	ALL	Body	Theft Deterrent Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade	Chassis	Suspension Control Module																																																										
4	2014	Escalade	Body	Body Control Module																																																										
4	2014	Escalade	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2014	Escalade	Body	Passenger Presence Module																																																										
4	2014	Escalade	Body	Instrument Cluster																																																										
4	2014	Escalade	Body	Radio																																																										
4	2014	Escalade	Body	Amplifier																																																										
4	2014	Escalade	Body	Rear Audio Control Module																																																										
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2014	Escalade	Body	HVAC Control Module																																																										
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Liftgate Control Module																																																										
4	2014	Escalade	Body	Seat Memory Control Module																																																										
4	2014	Escalade	Body	Rear Seat Heating Control Module																																																										
4	2014	Escalade	Body	Assist Step Control Module																																																										
4	2014	Escalade	Body	Right Side Object Detection Control Module																																																										
4	2014	Escalade	Body	Left Side Object Detection Control Module																																																										
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																																										
4	2014	Escalade	Body	Parking Assist Control Module																																																										
4	2014	Escalade	Body	Theft Deterrent Module																																																										
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2014	Escalade ESV	Body	Body Control Module																																																										
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2014	Escalade ESV	Body	Passenger Presence Module																																																										
4	2014	Escalade ESV	Body	Instrument Cluster																																																										
4	2014	Escalade ESV	Body	Radio																																																										
4	2014	Escalade ESV	Body	Amplifier																																																										
4	2014	Escalade ESV	Body	Rear Audio Control Module																																																										
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2014	Escalade ESV	Body	HVAC Control Module																																																										
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																										
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
4	2014	Escalade ESV	Body	Liftgate Control Module																																																											
4	2014	Escalade ESV	Body	Seat Memory Control Module																																																											
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																											
4	2014	Escalade ESV	Body	Assist Step Control Module																																																											
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																											
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																											
4	2014	Escalade ESV	Body	Parking Assist Control Module																																																											
4	2014	Escalade ESV	Body	Theft Deterrent Module																																																											
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																											
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																											
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																											
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																											
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																											
4	2015	Escalade	Chassis	Electronic Brake Control Module																																																											
4	2015	Escalade	Chassis	Parking Brake Control Module																																																											
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																											
4	2015	Escalade	Chassis	Power Steering Control Module																																																											
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																											
4	2015	Escalade	Chassis	Suspension Control Module																																																											
4	2015	Escalade	Body	Body Control Module																																																											
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
4	2015	Escalade	Body	Passenger Presence Module																																																											
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																											
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																											
4	2015	Escalade	Body	Instrument Cluster																																																											
4	2015	Escalade	Body	Radio/HVAC Control																																																											
4	2015	Escalade	Body	Active Safety Control Module																																																											
4	2015	Escalade	Body	Video Processing Control Module																																																											
4	2015	Escalade	Body	Radio																																																											
4	2015	Escalade	Body	Amplifier																																																											
4	2015	Escalade	Body	Media Disc Player																																																											
4	2015	Escalade	Body	Human Machine Interface Control Module																																																											
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																											
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																											
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																											
4	2015	Escalade	Body	HVAC Control Module																																																											
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																											
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																											
4	2015	Escalade	Body	Keyless Entry Control Module																																																											
4	2015	Escalade	Body	Assist Step Control Module																																																											
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
4	2015	Escalade	Body	Parking Assist Control Module																																																											
4	2015	Escalade	Body	Frontview Camera Module																																																												
4	2015	Escalade	Body	Steering Column Lock Control Module																																																												
4	2015	Escalade	Body	Battery Energy Control Module																																																												
4	2015	Escalade	Body	Long Range Radar Sensor Module																																																												
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																												
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																												
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																												
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																												
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																												
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																												
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																												
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																												
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																												
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																																												
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																												
4	2015	Escalade ESV	Chassis	Suspension Control Module																																																												
4	2015	Escalade ESV	Body	Body Control Module																																																												
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
4	2015	Escalade ESV	Body	Passenger Presence Module																																																												
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																												
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																												
4	2015	Escalade ESV	Body	Instrument Cluster																																																												
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																												
4	2015	Escalade ESV	Body	Active Safety Control Module																																																												
4	2015	Escalade ESV	Body	Video Processing Control Module																																																												
4	2015	Escalade ESV	Body	Radio																																																												
4	2015	Escalade ESV	Body	Amplifier																																																												
4	2015	Escalade ESV	Body	Media Disc Player																																																												
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																												
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																												
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																												
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																												
4	2015	Escalade ESV	Body	HVAC Control Module																																																												
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																											
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																											
4	2015	Escalade ESV	Body	Assist Step Control Module																																																											
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
4	2015	Escalade ESV	Body	Parking Assist Control Module																																																											
4	2015	Escalade ESV	Body	Frontview Camera Module																																																											
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
4	2016	Escalade	Chassis	Electronic Brake Control Module																																																										
4	2016	Escalade	Chassis	Parking Brake Control Module																																																										
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2016	Escalade	Chassis	Power Steering Control Module																																																										
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2016	Escalade	Chassis	Suspension Control Module																																																										
4	2016	Escalade	Body	Body Control Module																																																										
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2016	Escalade	Body	Passenger Presence Module																																																										
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2016	Escalade	Body	Instrument Cluster																																																										
4	2016	Escalade	Body	Radio/HVAC Control																																																										
4	2016	Escalade	Body	Active Safety Control Module																																																										
4	2016	Escalade	Body	Video Processing Control Module																																																										
4	2016	Escalade	Body	Radio																																																										
4	2016	Escalade	Body	Amplifier																																																										
4	2016	Escalade	Body	Media Disc Player																																																										
4	2016	Escalade	Body	Human Machine Interface Control Module																																																										
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																																										
4	2016	Escalade	Body	HVAC Control Module																																																										
4	2016	Escalade	Body	Liftgate Control Module																																																										
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																										
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																										
4	2016	Escalade	Body	Keyless Entry Control Module																																																										
4	2016	Escalade	Body	Assist Step Control Module																																																										
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																										
4	2016	Escalade	Body	Parking Assist Control Module																																																										
4	2016	Escalade	Body	Frontview Camera Module																																																										
4	2016	Escalade	Body	Steering Column Lock Control Module																																																										
4	2016	Escalade	Body	Long Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																										
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																																										
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2016	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2016	Escalade ESV	Body	Body Control Module																																																										
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2016	Escalade ESV	Body	Passenger Presence Module																																																										
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2016	Escalade ESV	Body	Instrument Cluster																																																										
4	2016	Escalade ESV	Body	Radio Control																																																										
4	2016	Escalade ESV	Body	HVAC Control																																																										
4	2016	Escalade ESV	Body	Active Safety Control Module																																																										
4	2016	Escalade ESV	Body	Video Processing Control Module																																																										
4	2016	Escalade ESV	Body	Radio																																																										
4	2016	Escalade ESV	Body	Amplifier																																																										
4	2016	Escalade ESV	Body	Media Disc Player																																																										
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																										
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																										
4	2016	Escalade ESV	Body	HVAC Control Module																																																										
4	2016	Escalade ESV	Body	Liftgate Control Module																																																										
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																										
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																										
4	2016	Escalade ESV	Body	Assist Step Control Module																																																										
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
4	2016	Escalade ESV	Body	Parking Assist Control Module																																																										
4	2016	Escalade ESV	Body	Frontview Camera Module																																																										
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																										
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																										
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																										
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																										
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																										
ALL	2004	Hearse	Chassis	DRP/ABS/TCS		V																																																								
ALL	2004	Hearse	Chassis	Magna Steer																																																										
ALL	2004	Hearse	Chassis	Rear Integration Module																																																										
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																										
ALL	2004	Hearse	Body	Amplifier (Delco)																																																										
ALL	2004	Hearse	Body	Dash Integration Module																																																										
ALL	2004	Hearse	Body	Driver Door Switch																																																										
ALL	2004	Hearse	Body	Driver Door Module																																																										
ALL	2004	Hearse	Body	Passenger Door Module																																																										
ALL	2004	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2004	Hearse	Body	Instrument Panel Module																											V																															
ALL	2004	Hearse	Body	Personalization																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
ALL	2004	Hearse	Body	Radio																																																											
ALL	2004	Hearse	Body	Rear Integration Module																																																											
ALL	2004	Hearse	Body	Remote Function Actuation																																																											
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																																																											
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																																											
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																											
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																											
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																											
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																											
ALL	2004	Limousine	Chassis	DRP/ABS/TCS		V																																																									
ALL	2004	Limousine	Chassis	Magna Steer																																																											
ALL	2004	Limousine	Chassis	Rear Integration Module																																																											
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																											
ALL	2004	Limousine	Body	Amplifier (Delco)																																																											
ALL	2004	Limousine	Body	Dash Integration Module																																																											
ALL	2004	Limousine	Body	Driver Door Switch																																																											
ALL	2004	Limousine	Body	Driver Door Module																																																											
ALL	2004	Limousine	Body	Passenger Door Module																																																											
ALL	2004	Limousine	Body	Left Mid Door Module																																																											
ALL	2004	Limousine	Body	Left Rear Door Module																																																											
ALL	2004	Limousine	Body	Right Mid Door Module																																																											
ALL	2004	Limousine	Body	Right Rear Door Module																																																											
ALL	2004	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2004	Limousine	Body	Instrument Panel Module																												V																															
ALL	2004	Limousine	Body	Memory Seat Module																																																											
ALL	2004	Limousine	Body	Navigation Radio																																																											
ALL	2004	Limousine	Body	Personalization																																																											
ALL	2004	Limousine	Body	Radio																																																											
ALL	2004	Limousine	Body	Rear Climate Control Panel																																																											
ALL	2004	Limousine	Body	Rear Integration Module																																																											
ALL	2004	Limousine	Body	Remote Function Actuation																																																											
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																																																											
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																																											
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																											
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																											
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																											
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																											
ALL	2005	Hearse	Chassis	DRP/ABS/TCS		V																																																									
ALL	2005	Hearse	Chassis	Magna Steer																																																											
ALL	2005	Hearse	Chassis	Rear Integration Module																																																											
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																											
ALL	2005	Hearse	Body	Amplifier (Delco)																																																											
ALL	2005	Hearse	Body	Dash Integration Module																																																											
ALL	2005	Hearse	Body	Driver Door Switch																																																											
ALL	2005	Hearse	Body	Driver Door Module																																																											
ALL	2005	Hearse	Body	Passenger Door Module																																																											
ALL	2005	Hearse	Body	Instrument Panel Cluster																																																											
ALL	2005	Hearse	Body	Instrument Panel Module																												V																															
ALL	2005	Hearse	Body	Personalization																																																											
ALL	2005	Hearse	Body	Radio																																																											
ALL	2005	Hearse	Body	Rear Integration Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
ALL	2005	Hearse	Body	Remote Function Actuation																																																										
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																																										
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																										
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																										
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																										
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																										
ALL	2005	Limousine	Chassis	DRP/ABS/TCS		V																																																									
ALL	2005	Limousine	Chassis	Magna Steer																																																										
ALL	2005	Limousine	Chassis	Rear Integration Module																																																										
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																										
ALL	2005	Limousine	Body	Amplifier (Delco)																																																										
ALL	2005	Limousine	Body	Dash Integration Module																																																										
ALL	2005	Limousine	Body	Driver Door Switch																																																										
ALL	2005	Limousine	Body	Driver Door Module																																																										
ALL	2005	Limousine	Body	Passenger Door Module																																																										
ALL	2005	Limousine	Body	Left Mid Door Module																																																										
ALL	2005	Limousine	Body	Left Rear Door Module																																																										
ALL	2005	Limousine	Body	Right Mid Door Module																																																										
ALL	2005	Limousine	Body	Right Rear Door Module																																																										
ALL	2005	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2005	Limousine	Body	Instrument Panel Module																												V																															
ALL	2005	Limousine	Body	Memory Seat Module																																																										
ALL	2005	Limousine	Body	Navigation Radio																																																										
ALL	2005	Limousine	Body	Personalization																																																										
ALL	2005	Limousine	Body	Radio																																																										
ALL	2005	Limousine	Body	Rear Climate Control Panel																																																										
ALL	2005	Limousine	Body	Rear Integration Module																																																										
ALL	2005	Limousine	Body	Remote Function Actuation																																																										
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																																										
ALL	2006	Hearse	Powertrain	Engine Control Module																																																										
ALL	2006	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2006	Hearse	Body	Amplifier (Bose)																																																										
ALL	2006	Hearse	Body	Body Control Module															V	V	V	V	V	V	V		V	V																																		
ALL	2006	Hearse	Body	Digital Radio Receiver																																																										
ALL	2006	Hearse	Body	Driver Door Switch																																																										
ALL	2006	Hearse	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																			
ALL	2006	Hearse	Body	HVAC Control Module																												V	V																													
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2006	Hearse	Body	Passenger Door Switch																																																										
ALL	2006	Hearse	Body	Passenger Presence System																																										V																
ALL	2006	Hearse	Body	Radio																																																									
ALL	2006	Hearse	Body	Rear Heated Seat Module																																	V				V																			
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																										V										V					
ALL	2006	Hearse	Body	Theft Deterrent Module																																																										
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
ALL	2006	Limousine	Powertrain	Engine Control Module																																																									
ALL	2006	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2006	Limousine	Body	Amplifier (Bose)																																																										
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2006	Limousine	Body	Body Control Module															V	V	V	V	V	V	V		V	V																																		
ALL	2006	Limousine	Body	Digital Radio Receiver																																																										
ALL	2006	Limousine	Body	Driver Door Switch																																																										
ALL	2006	Limousine	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																				
ALL	2006	Limousine	Body	HVAC Control Module																											V	V																															
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2006	Limousine	Body	Passenger Door Switch																																																										
ALL	2006	Limousine	Body	Passenger Presence System																																										V																
ALL	2006	Limousine	Body	Radio																																																										
ALL	2006	Limousine	Body	Rear Heated Seat Module																																	V				V																					
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																										V										V					
ALL	2006	Limousine	Body	Theft Deterrent Module																																																										
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																																										
ALL	2007	Hearse	Powertrain	Engine Control Module																																																										
ALL	2007	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Hearse	Body	Amplifier (Bose)																																																										
ALL	2007	Hearse	Body	Body Control Module															V	V	V	V	V	V	V		V	V																																		
ALL	2007	Hearse	Body	Digital Radio Receiver																																																										
ALL	2007	Hearse	Body	Driver Door Switch																																																										
ALL	2007	Hearse	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																				
ALL	2007	Hearse	Body	HVAC Control Module																											V	V																															
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2007	Hearse	Body	Passenger Door Switch																																																										
ALL	2007	Hearse	Body	Passenger Presence System																																										V																
ALL	2007	Hearse	Body	Radio																																																										
ALL	2007	Hearse	Body	Rear Heated Seat Module																																	V				V																					
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																										V										V					
ALL	2007	Hearse	Body	Theft Deterrent Module																																																										
ALL	2007	Limousine	Powertrain	Engine Control Module																																																										
ALL	2007	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Limousine	Body	Amplifier (Bose)																																																										
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2007	Limousine	Body	Body Control Module															V	V	V	V	V	V	V		V	V																																		
ALL	2007	Limousine	Body	Digital Radio Receiver																																																										
ALL	2007	Limousine	Body	Driver Door Switch																																																										
ALL	2007	Limousine	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																				
ALL	2007	Limousine	Body	HVAC Control Module																											V	V																															
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2007	Limousine	Body	Passenger Door Switch																																																										
ALL	2007	Limousine	Body	Passenger Presence System																																									V																
ALL	2007	Limousine	Body	Radio																																																									
ALL	2007	Limousine	Body	Rear Heated Seat Module																																	V				V																					
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																									V									V						
ALL	2007	Limousine	Body	Theft Deterrent Module																																																									
ALL	2008	Hearse	Powertrain	Engine Control Module																																																										
ALL	2008	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2008	Hearse	Body	Amplifier (Bose)																																																										
ALL	2008	Hearse	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V																																		
ALL	2008	Hearse	Body	Climate Control Seat Module																																																										
ALL	2008	Hearse	Body	Digital Radio Receiver																																																										
ALL	2008	Hearse	Body	Driver Door Switch																																																										
ALL	2008	Hearse	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																				
ALL	2008	Hearse	Body	HVAC Control Module																												V	V																														
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2008	Hearse	Body	Passenger Door Switch																																																										
ALL	2008	Hearse	Body	Passenger Presence System																																									V																
ALL	2008	Hearse	Body	Radio																																																										
ALL	2008	Hearse	Body	Rear Heated Seat Module																																	V				V																					
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																									V									V						
ALL	2008	Hearse	Body	Theft Deterrent Module																																																										
ALL	2008	Limousine	Powertrain	Engine Control Module																																																											
ALL	2008	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2008	Limousine	Body	Amplifier (Bose)																																																										
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2008	Limousine	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V																																		
ALL	2008	Limousine	Body	Climate Control Seat Module																																																										
ALL	2008	Limousine	Body	Digital Radio Receiver																																																										
ALL	2008	Limousine	Body	Driver Door Switch																																																										
ALL	2008	Limousine	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																			
ALL	2008	Limousine	Body	HVAC Control Module																												V	V																													
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2008	Limousine	Body	Passenger Door Switch																																																										
ALL	2008	Limousine	Body	Passenger Presence System																																									V																
ALL	2008	Limousine	Body	Radio																																																										
ALL	2008	Limousine	Body	Rear Heated Seat Module																																	V				V																					
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																									V									V						
ALL	2008	Limousine	Body	Theft Deterrent Module																																																										
ALL	2009	Hearse	Powertrain	Engine Control Module																																																											
ALL	2009	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2009	Hearse	Body	Amplifier (Bose)																																																										
ALL	2009	Hearse	Body	Body Control Module															V	V	V	V	V		V		V	V																																		
ALL	2009	Hearse	Body	Climate Control Seat Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
ALL	2009	Hearse	Body	Digital Radio Receiver																																																										
ALL	2009	Hearse	Body	Driver Door Switch																																																										
ALL	2009	Hearse	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																				
ALL	2009	Hearse	Body	HVAC Control Module																											V	V																														
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2009	Hearse	Body	Passenger Door Switch																																																										
ALL	2009	Hearse	Body	Passenger Presence System																																										V																
ALL	2009	Hearse	Body	Radio																																																										
ALL	2009	Hearse	Body	Rear Heated Seat Module																																	V				V																					
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																										V										V						
ALL	2009	Hearse	Body	Theft Deterrent Module																																																										
ALL	2009	Limousine	Powertrain	Engine Control Module																																																										
ALL	2009	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2009	Limousine	Body	Amplifier (Bose)																																																										
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2009	Limousine	Body	Body Control Module															V	V	V	V	V		V		V	V																																		
ALL	2009	Limousine	Body	Climate Control Seat Module																																																										
ALL	2009	Limousine	Body	Digital Radio Receiver																																																										
ALL	2009	Limousine	Body	Driver Door Switch																																																										
ALL	2009	Limousine	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																				
ALL	2009	Limousine	Body	HVAC Control Module																											V	V																														
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2009	Limousine	Body	Passenger Door Switch																																																										
ALL	2009	Limousine	Body	Passenger Presence System																																										V																
ALL	2009	Limousine	Body	Radio																																																										
ALL	2009	Limousine	Body	Rear Heated Seat Module																																	V				V																					
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																										V										V						
ALL	2009	Limousine	Body	Theft Deterrent Module																																																										
ALL	2010	Hearse	Powertrain	Engine Control Module																																																										
ALL	2010	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2010	Hearse	Body	Amplifier (Bose)																																																										
ALL	2010	Hearse	Body	Body Control Module															V	V	V	V	V		V		V	V																																		
ALL	2010	Hearse	Body	Climate Control Seat Module																																																										
ALL	2010	Hearse	Body	Digital Radio Receiver																																																										
ALL	2010	Hearse	Body	Driver Door Switch																																																										
ALL	2010	Hearse	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																				
ALL	2010	Hearse	Body	HVAC Control Module																											V	V																														
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2010	Hearse	Body	Passenger Door Switch																																																										
ALL	2010	Hearse	Body	Passenger Presence System																																										V																
ALL	2010	Hearse	Body	Radio																																																										
ALL	2010	Hearse	Body	Rear Heated Seat Module																																	V				V																					
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																										V										V						
ALL	2010	Hearse	Body	Theft Deterrent Module																																																										
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	Limousine	Powertrain	Engine Control Module																																																										
ALL	2010	Limousine	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																									
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																																									
ALL	2010	Limousine	Body	Amplifier (Bose)																																																									
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																									
ALL	2010	Limousine	Body	Body Control Module															V	V	V	V	V		V		V	V																																	
ALL	2010	Limousine	Body	Climate Control Seat Module																																																									
ALL	2010	Limousine	Body	Digital Radio Receiver																																																									
ALL	2010	Limousine	Body	Driver Door Switch																																																									
ALL	2010	Limousine	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																			
ALL	2010	Limousine	Body	HVAC Control Module																											V	V																														
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2010	Limousine	Body	Passenger Door Switch																																																									
ALL	2010	Limousine	Body	Passenger Presence System																																									V																
ALL	2010	Limousine	Body	Radio																																																									
ALL	2010	Limousine	Body	Rear Heated Seat Module																																	V				V																			
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																									V									V					
ALL	2010	Limousine	Body	Theft Deterrent Module																																																									
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																																									
ALL	2011	Hearse	Powertrain	Engine Control Module																																																									
ALL	2011	Hearse	Powertrain	Transmission Control Module		V																																																							
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																									
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																																									
ALL	2011	Hearse	Body	Amplifier (Bose)																																																									
ALL	2011	Hearse	Body	Body Control Module															V	V	V	V	V		V		V	V																																	
ALL	2011	Hearse	Body	Climate Control Seat Module																																																									
ALL	2011	Hearse	Body	Digital Radio Receiver																																																									
ALL	2011	Hearse	Body	Driver Door Switch																																																									
ALL	2011	Hearse	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																			
ALL	2011	Hearse	Body	HVAC Control Module																											V	V																														
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																									
ALL	2011	Hearse	Body	Passenger Door Switch																																																									
ALL	2011	Hearse	Body	Passenger Presence System																																									V																
ALL	2011	Hearse	Body	Radio																																																									
ALL	2011	Hearse	Body	Rear Heated Seat Module																																	V				V																			
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																									V									V					
ALL	2011	Hearse	Body	Theft Deterrent Module																																																									
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																																									
ALL	2011	Limousine	Powertrain	Engine Control Module																																																									
ALL	2011	Limousine	Powertrain	Transmission Control Module		V																																																							
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																									
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																																									
ALL	2011	Limousine	Body	Amplifier (Bose)																																																									
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																									
ALL	2011	Limousine	Body	Body Control Module															V	V	V	V	V		V		V	V																																	
ALL	2011	Limousine	Body	Climate Control Seat Module																																																									
ALL	2011	Limousine	Body	Digital Radio Receiver																																																									
ALL	2011	Limousine	Body	Driver Door Switch																																																									
ALL	2011	Limousine	Body	Driver Position Module																														V	V	V	V	V	V	V	V	V																			
ALL	2011	Limousine	Body	HVAC Control Module																											V	V																														
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2011	Limousine	Body	Passenger Door Switch																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
ALL	2011	Limousine	Body	Passenger Presence System																																										V																
ALL	2011	Limousine	Body	Radio																																																									
ALL	2011	Limousine	Body	Rear Heated Seat Module																																	V				V																					
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																										V										V					
ALL	2011	Limousine	Body	Theft Deterrent Module																																																									
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																												
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2004	ALL	Chassis	ESC																																																											
C	2004	ALL	Chassis	Rear Wheel Steering																																																												
C	2004	ALL	Chassis	Tire Pressure Monitor																																																												
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2004	ALL	Chassis	VSES																																																											
C	2004	ALL	Body	Amplifier (Bose)																																																												
C	2004	ALL	Body	Body Control Module																																																											
C	2004	ALL	Body	CD Changer																																																											
C	2004	ALL	Body	Chime																																																											
C	2004	ALL	Body	Driver Door Module																																																											
C	2004	ALL	Body	Driver Seat Module																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
C	2004	ALL	Body	Instrument Panel Cluster																																																											
C	2004	ALL	Body	OnStar																																																										
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Base Radio																																																										
C	2004	ALL	Body	Uplevel Radio																																																										
C	2004	ALL	Body	Navigation Radio																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																											
C	2004	ALL	Body	Rear HVAC																																																											
C	2004	ALL	Body	Rear Seat Audio																																																											
C	2004	ALL	Body	Rear Seat Entertainment																																																											
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																											
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																											
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2005	ALL	Chassis	ESC																																																										
C	2005	ALL	Chassis	Rear Wheel Steering																																																											
C	2005	ALL	Chassis	Tire Pressure Monitor																																																											
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2005	ALL	Chassis	VSES																																																										
C	2005	ALL	Body	Amplifier (Bose)																																																											
C	2005	ALL	Body	Body Control Module																																																											
C	2005	ALL	Body	CD Changer																																																											
C	2005	ALL	Body	Chime																																																											
C	2005	ALL	Body	Disc Player and Video Display																																																											
C	2005	ALL	Body	Driver Door Module																																																											
C	2005	ALL	Body	Driver Seat Module																																																											
C	2005	ALL	Body	Generator Battery Control Module																																																											
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																														
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																														
C	2005	ALL	Body	Instrument Panel Cluster																																																														
C	2005	ALL	Body	Passenger Door Module																																																														
C	2005	ALL	Body	Passenger Presence System																																																														
C	2005	ALL	Body	Base Radio																																																														
C	2005	ALL	Body	Uplevel Radio																																																														
C	2005	ALL	Body	Navigation Radio																																																														
C	2005	ALL	Body	Rear Aux. Climate Module																																																														
C	2005	ALL	Body	Rear HVAC																																																														
C	2005	ALL	Body	Rear Seat Audio																																																														
C	2005	ALL	Body	Remote Function Actuation																																																														
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																														
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																														
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																														
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																														
C	2006	ALL	Chassis	ESC																																																														
C	2006	ALL	Chassis	Tire Pressure Monitor																																																														
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																														
C	2006	ALL	Chassis	VSES																																																														
C	2006	ALL	Body	Amplifier (Bose)																																																														
C	2006	ALL	Body	Body Control Module																																																														
C	2006	ALL	Body	CD Changer																																																														
C	2006	ALL	Body	Chime																																																														
C	2006	ALL	Body	Disc Player and Video Display																																																														
C	2006	ALL	Body	Driver Door Module																																																														
C	2006	ALL	Body	Driver Seat Module																																																														
C	2006	ALL	Body	Generator Battery Control Module																																																														
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																														
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																														
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																														
C	2006	ALL	Body	Instrument Panel Cluster																																																														
C	2006	ALL	Body	Passenger Door Module																																																														
C	2006	ALL	Body	Passenger Presence System																																																														
C	2006	ALL	Body	Base Radio																																																														
C	2006	ALL	Body	Uplevel Radio																																																														
C	2006	ALL	Body	Navigation Radio																																																														
C	2006	ALL	Body	Rear Aux. Climate Module																																																														
C	2006	ALL	Body	Rear HVAC																																																														
C	2006	ALL	Body	Rear Seat Audio																																																														
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																														
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																														
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																														
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																														
C	2007	ALL	Chassis	Electronic Brake Control Module																																																														
C	2007	ALL	Chassis	Electronic Suspension Control																																																														
C	2007	ALL	Body	Amplifier (Bose)																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2007	ALL	Body	Assist Step Controller																																																													
C	2007	ALL	Body	Body Control Module																																																													
C	2007	ALL	Body	Body Control Module (aux.)																																																													
C	2007	ALL	Body	Digital Radio Receiver																																																													
C	2007	ALL	Body	Driver Door Switch																																																													
C	2007	ALL	Body	HVAC Control Module																																																													
C	2007	ALL	Body	Inside Rear View Mirror Module																																																													
C	2007	ALL	Body	Instrument Panel Cluster																																																													
C	2007	ALL	Body	Lift Gate Module																									V	V																																				
C	2007	ALL	Body	Memory Seat Module																																																													
C	2007	ALL	Body	Park Assist Module																																																													
C	2007	ALL	Body	Passenger Door Switch																																																													
C	2007	ALL	Body	Passenger Presence System																																																													
C	2007	ALL	Body	Radio																																																													
C	2007	ALL	Body	Rear Heated Seat Module																																																													
C	2007	ALL	Body	Rear HVAC/RSA																																																													
C	2007	ALL	Body	Rollover Sensor																																																													
C	2007	ALL	Body	Supplemental Inflatable Restraint																																																													
C	2007	ALL	Body	Theft Deterrent Module																																																													
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																														
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																													
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																													
C	2008	ALL	Chassis	Electronic Brake Control Module			V																																																										
C	2008	ALL	Chassis	Electronic Suspension Control																																																													
C	2008	ALL	Chassis	Trailer Brake Control Module																																																													
C	2008	ALL	Body	Amplifier (Bose)																																																													
C	2008	ALL	Body	Assist Step Controller																																																													
C	2008	ALL	Body	Body Control Module																																																													
C	2008	ALL	Body	Body Control Module (aux.)																																																													
C	2008	ALL	Body	Digital Radio Receiver																																																													
C	2008	ALL	Body	Driver Door Switch																																																													
C	2008	ALL	Body	HVAC Control Module																																																													
C	2008	ALL	Body	Inside Rear View Mirror Module																																																													
C	2008	ALL	Body	Instrument Panel Cluster																																																													
C	2008	ALL	Body	Lift Gate Module																									V	V																																				
C	2008	ALL	Body	Memory Seat Module																																																													
C	2008	ALL	Body	Park Assist Module																																																													
C	2008	ALL	Body	Passenger Door Switch																																																													
C	2008	ALL	Body	Passenger Presence System																																																													
C	2008	ALL	Body	Radio																																																													
C	2008	ALL	Body	Rear Heated Seat Module																																																													
C	2008	ALL	Body	Rear HVAC/RSA																																																													
C	2008	ALL	Body	Rollover Sensor																																																													
C	2008	ALL	Body	Supplemental Inflatable Restraint																																																													
C	2008	ALL	Body	Theft Deterrent Module																																																													
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																			
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
C	2009	ALL	Chassis	Electronic Brake Control Module			V																																																										
C	2009	ALL	Chassis	Electronic Suspension Control																																																													
C	2009	ALL	Chassis	Trailer Brake Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2009	ALL	Body	Amplifier (Bose)																																																														
C	2009	ALL	Body	Assist Step Controller																																																														
C	2009	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																									
C	2009	ALL	Body	Body Control Module (aux.)																																																														
C	2009	ALL	Body	Digital Radio Receiver																																																														
C	2009	ALL	Body	Driver Door Switch																																																														
C	2009	ALL	Body	HVAC Control Module																																																														
C	2009	ALL	Body	Inside Rear View Mirror Module																																																														
C	2009	ALL	Body	Instrument Panel Cluster																																																														
C	2009	ALL	Body	Left Side Object Detection Module						V																																																								
C	2009	ALL	Body	Lift Gate Module																									V	V																																					
C	2009	ALL	Body	Memory Seat Module																																																														
C	2009	ALL	Body	Park Assist Module																																																														
C	2009	ALL	Body	Passenger Door Switch																																																														
C	2009	ALL	Body	Passenger Presence System																																																														
C	2009	ALL	Body	Radio																																																														
C	2009	ALL	Body	Rear Heated Seat Module																																																														
C	2009	ALL	Body	Rear HVAC/RSA																																																														
C	2009	ALL	Body	Right Side Object Detection Module						V																																																								
C	2009	ALL	Body	Rollover Sensor																																																														
C	2009	ALL	Body	Supplemental Inflatable Restraint																																																														
C	2009	ALL	Body	Theft Deterrent Module																																																														
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																															
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																														
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
C	2010	ALL	Chassis	Electronic Brake Control Module			V																																																											
C	2010	ALL	Chassis	Electronic Suspension Control																																																														
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	ALL	Body	Amplifier (Bose)																																																														
C	2010	ALL	Body	Assist Step Controller																																																														
C	2010	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																									
C	2010	ALL	Body	Body Control Module (aux.)																																																														
C	2010	ALL	Body	Digital Radio Receiver																																																														
C	2010	ALL	Body	Driver Door Switch																																																														
C	2010	ALL	Body	HVAC Control Module																																																														
C	2010	ALL	Body	Inside Rear View Mirror Module																																																														
C	2010	ALL	Body	Instrument Panel Cluster																																																														
C	2010	ALL	Body	Left Side Object Detection Module						V																																																								
C	2010	ALL	Body	Lift Gate Module																									V	V			V	V																																	
C	2010	ALL	Body	Memory Seat Module																																																														
C	2010	ALL	Body	Park Assist Module																																																														
C	2010	ALL	Body	Passenger Door Switch																																																														
C	2010	ALL	Body	Passenger Presence System																																																														
C	2010	ALL	Body	Radio																																																														
C	2010	ALL	Body	Rear Heated Seat Module																																																														
C	2010	ALL	Body	Rear HVAC/RSA																																																														
C	2010	ALL	Body	Right Side Object Detection Module						V																																																								
C	2010	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2010	ALL	Body	Theft Deterrent Module																																																												
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																																												
E	2004	ALL	Chassis	Electronic Suspension Control																																																												
E	2004	ALL	Chassis	Tire Pressure Monitor																																																												
E	2004	ALL	Chassis	VES																																																												
E	2004	ALL	Body	Amplifier (Bose)																																																												
E	2004	ALL	Body	Amplifier (Delco)																																																												
E	2004	ALL	Body	Climate Control Panel																																																												
E	2004	ALL	Body	Dash Integration Module																																																												
E	2004	ALL	Body	Disc Player and Video Display																																																												
E	2004	ALL	Body	Driver Door Switch																																																												
E	2004	ALL	Body	Driver Door Module																																																												
E	2004	ALL	Body	Passenger Door Module																																																												
E	2004	ALL	Body	Left Rear Door Module																																																												
E	2004	ALL	Body	Right Rear Door Module																																																												
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																												
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																												
E	2004	ALL	Body	Instrument Panel Cluster																																																												
E	2004	ALL	Body	Memory Seat Module																																																												
E	2004	ALL	Body	OnStar																																																												
E	2004	ALL	Body	Personalization																																																												
E	2004	ALL	Body	Base Radio																																																												
E	2004	ALL	Body	Navigation Radio																																																												
E	2004	ALL	Body	Rear Integration Module																																																												
E	2004	ALL	Body	Rear Seat Module																																																												
E	2004	ALL	Body	Remote Function Actuation																																																												
E	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2004	ALL	Body	TV Antenna Module																																																												
E	2004	ALL	Body	Vehicle Theft Deterrent																																																												
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																																												
E	2005	ALL	Chassis	Electronic Suspension Control																																																												
E	2005	ALL	Chassis	Tire Pressure Monitor																																																												
E	2005	ALL	Chassis	VES																																																												
E	2005	ALL	Body	Amplifier (Bose)																																																												
E	2005	ALL	Body	Amplifier (Delco)																																																												
E	2005	ALL	Body	Climate Control Panel																																																												
E	2005	ALL	Body	Dash Integration Module																																																												
E	2005	ALL	Body	Disc Player and Video Display																																																												
E	2005	ALL	Body	Driver Door Switch																																																												
E	2005	ALL	Body	Driver Door Module																																																												
E	2005	ALL	Body	Passenger Door Module																																																												
E	2005	ALL	Body	Left Rear Door Module																																																												
E	2005	ALL	Body	Right Rear Door Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																													
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																													
E	2005	ALL	Body	Instrument Panel Cluster																																																													
E	2005	ALL	Body	Memory Seat Module																																																													
E	2005	ALL	Body	Personalization																																																													
E	2005	ALL	Body	Base Radio																																																													
E	2005	ALL	Body	Navigation Radio																																																													
E	2005	ALL	Body	Rear Integration Module																																																													
E	2005	ALL	Body	Rear Seat Module																																																													
E	2005	ALL	Body	Remote Function Actuation																																																													
E	2005	ALL	Body	Supplemental Inflatable Restraint																																																													
E	2005	ALL	Body	TV Antenna Module																																																													
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																													
E	2005	ALL	Body	Vehicle Theft Deterrent																																																													
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																													
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																													
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																													
E	2006	ALL	Chassis	Electronic Suspension Control																																																													
E	2006	ALL	Chassis	Tire Pressure Monitor																																																													
E	2006	ALL	Chassis	VES																																																													
E	2006	ALL	Body	Amplifier (Bose)																																																													
E	2006	ALL	Body	Amplifier (Delco)																																																													
E	2006	ALL	Body	Climate Control Panel																																																													
E	2006	ALL	Body	Dash Integration Module																																																													
E	2006	ALL	Body	Disc Player and Video Display																																																													
E	2006	ALL	Body	Driver Door Switch																																																													
E	2006	ALL	Body	Driver Door Module																																																													
E	2006	ALL	Body	Passenger Door Module																																																													
E	2006	ALL	Body	Left Rear Door Module																																																													
E	2006	ALL	Body	Right Rear Door Module																																																													
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																													
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																													
E	2006	ALL	Body	Instrument Panel Cluster																																																													
E	2006	ALL	Body	Lift Gate Module																														V																															
E	2006	ALL	Body	Memory Seat Module																																																													
E	2006	ALL	Body	Personalization																																																													
E	2006	ALL	Body	Base Radio																																																													
E	2006	ALL	Body	Navigation Radio																																																													
E	2006	ALL	Body	Rear Integration Module																																																													
E	2006	ALL	Body	Rear Seat Module																																																													
E	2006	ALL	Body	Remote Function Actuation																																																													
E	2006	ALL	Body	Supplemental Inflatable Restraint																																																													
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																													
E	2006	ALL	Body	Vehicle Theft Deterrent																																																													
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																													
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																													
E	2007	ALL	Chassis	Electronic Brake Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
E	2007	ALL	Chassis	Electronic Suspension Control																																																												
E	2007	ALL	Body	Amplifier (Bose)																																																												
E	2007	ALL	Body	Body Control Module																																																												
E	2007	ALL	Body	Body Control Module (aux.)																																																												
E	2007	ALL	Body	Digital Radio Receiver																																																												
E	2007	ALL	Body	Driver Door Switch																																																												
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																												
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																												
E	2007	ALL	Body	HVAC Control Module																																																												
E	2007	ALL	Body	Instrument Panel Cluster																																																												
E	2007	ALL	Body	Lift Gate Module																									V	V																																		
E	2007	ALL	Body	Memory Seat Module																																																												
E	2007	ALL	Body	Park Assist Module																																																												
E	2007	ALL	Body	Passenger Door Switch																																																												
E	2007	ALL	Body	Passenger Presence System																																																												
E	2007	ALL	Body	Radio																																																												
E	2007	ALL	Body	Rear HVAC/RSA																																																												
E	2007	ALL	Body	Rear Seat Module																																																												
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																												
E	2007	ALL	Body	Rollover Sensor																																																												
E	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2007	ALL	Body	Theft Deterrent Module																																																												
E	2007	ALL	Body	TV Antenna Module																																																												
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2008	ALL	Chassis	Electronic Brake Control Module																																																												
E	2008	ALL	Chassis	Electronic Suspension Control																																																												
E	2008	ALL	Body	Amplifier (Bose)																																																												
E	2008	ALL	Body	Body Control Module																																																												
E	2008	ALL	Body	Body Control Module (aux.)																																																												
E	2008	ALL	Body	Digital Radio Receiver																																																												
E	2008	ALL	Body	Driver Door Switch																																																												
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																												
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																												
E	2008	ALL	Body	HVAC Control Module																																																												
E	2008	ALL	Body	Instrument Panel Cluster																																																												
E	2008	ALL	Body	Lift Gate Module																									V	V																																		
E	2008	ALL	Body	Memory Seat Module																																																												
E	2008	ALL	Body	Park Assist Module																																																												
E	2008	ALL	Body	Passenger Door Switch																																																												
E	2008	ALL	Body	Passenger Presence System																																																												
E	2008	ALL	Body	Radio																																																												
E	2008	ALL	Body	Rear HVAC/RSA																																																												
E	2008	ALL	Body	Rear Seat Module																																																												
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																												
E	2008	ALL	Body	Rollover Sensor																																																												
E	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2008	ALL	Body	Theft Deterrent Module																																																												
E	2008	ALL	Body	TV Antenna Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module										V																																																			
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																													
E	2009	ALL	Chassis	Electronic Brake Control Module																																																													
E	2009	ALL	Chassis	Electronic Suspension Control																																																													
E	2009	ALL	Body	Amplifier (Bose)																																																													
E	2009	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																								
E	2009	ALL	Body	Body Control Module (aux.)																																																													
E	2009	ALL	Body	Digital Radio Receiver																																																													
E	2009	ALL	Body	Driver Door Switch																																																													
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																													
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																													
E	2009	ALL	Body	HVAC Control Module																																																													
E	2009	ALL	Body	Instrument Panel Cluster																																																													
E	2009	ALL	Body	Lift Gate Module																									V	V			V	V																																
E	2009	ALL	Body	Memory Seat Module																																																													
E	2009	ALL	Body	Park Assist Module																																																													
E	2009	ALL	Body	Passenger Door Switch																																																													
E	2009	ALL	Body	Passenger Presence System																																																													
E	2009	ALL	Body	Radio																																																													
E	2009	ALL	Body	Rear HVAC/RSA																																																													
E	2009	ALL	Body	Rear Seat Module																																																													
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																													
E	2009	ALL	Body	Rollover Sensor																																																													
E	2009	ALL	Body	Supplemental Inflatable Restraint																																																													
E	2009	ALL	Body	Theft Deterrent Module																																																													
E	2009	ALL	Body	TV Antenna Module																																																													
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																													
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																													
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																													
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																													
K	2004	ALL	Chassis	ESC																																																													
K	2004	ALL	Chassis	Rear Wheel Steering																																																													
K	2004	ALL	Chassis	Tire Pressure Monitor																																																													
K	2004	ALL	Chassis	VSES																																																													
K	2004	ALL	Body	Amplifier (Bose)																																																													
K	2004	ALL	Body	Body Control Module																																																													
K	2004	ALL	Body	CD Changer																																																													
K	2004	ALL	Body	Chime																																																													
K	2004	ALL	Body	Driver Door Module																																																													
K	2004	ALL	Body	Driver Seat Module																																																													
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																													
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																													
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																													
K	2004	ALL	Body	Instrument Panel Cluster																																																													
K	2004	ALL	Body	OnStar																																																													
K	2004	ALL	Body	Passenger Door Module																																																													
K	2004	ALL	Body	Passenger Presence System																																																													
K	2004	ALL	Body	Base Radio																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2004	ALL	Body	Uplevel Radio																																																														
K	2004	ALL	Body	Navigation Radio																																																														
K	2004	ALL	Body	Rear Aux. Climate Module																																																														
K	2004	ALL	Body	Rear HVAC																																																														
K	2004	ALL	Body	Rear Seat Audio																																																														
K	2004	ALL	Body	Rear Seat Entertainment																																																														
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																														
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																														
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																														
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																														
K	2005	ALL	Chassis	ESC																																																														
K	2005	ALL	Chassis	Rear Wheel Steering																																																														
K	2005	ALL	Chassis	Tire Pressure Monitor																																																														
K	2005	ALL	Chassis	VSES																																																														
K	2005	ALL	Body	Amplifier (Bose)																																																														
K	2005	ALL	Body	Body Control Module																																																														
K	2005	ALL	Body	CD Changer																																																														
K	2005	ALL	Body	Chime																																																														
K	2005	ALL	Body	Disc Player and Video Display																																																														
K	2005	ALL	Body	Driver Door Module																																																														
K	2005	ALL	Body	Driver Seat Module																																																														
K	2005	ALL	Body	Generator Battery Control Module																																																														
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																														
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																														
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																														
K	2005	ALL	Body	Instrument Panel Cluster																																																														
K	2005	ALL	Body	Passenger Door Module																																																														
K	2005	ALL	Body	Passenger Presence System																																																														
K	2005	ALL	Body	Base Radio																																																														
K	2005	ALL	Body	Uplevel Radio																																																														
K	2005	ALL	Body	Navigation Radio																																																														
K	2005	ALL	Body	Rear Aux. Climate Module																																																														
K	2005	ALL	Body	Rear HVAC																																																														
K	2005	ALL	Body	Rear Seat Audio																																																														
K	2005	ALL	Body	Remote Function Actuation																																																														
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																														
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																														
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																														
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																														
K	2006	ALL	Chassis	ESC																																																														
K	2006	ALL	Chassis	Tire Pressure Monitor																																																														
K	2006	ALL	Chassis	VSES																																																														
K	2006	ALL	Body	Amplifier (Bose)																																																														
K	2006	ALL	Body	Body Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2006	ALL	Body	CD Changer																																																												
K	2006	ALL	Body	Chime																																																												
K	2006	ALL	Body	Disc Player and Video Display																																																												
K	2006	ALL	Body	Driver Door Module																																																												
K	2006	ALL	Body	Driver Seat Module																																																												
K	2006	ALL	Body	Generator Battery Control Module																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2006	ALL	Body	Instrument Panel Cluster																																																												
K	2006	ALL	Body	Passenger Door Module																																																												
K	2006	ALL	Body	Passenger Presence System																																																												
K	2006	ALL	Body	Base Radio																																																												
K	2006	ALL	Body	Uplevel Radio																																																												
K	2006	ALL	Body	Navigation Radio																																																												
K	2006	ALL	Body	Rear Aux. Climate Module																																																												
K	2006	ALL	Body	Rear HVAC																																																												
K	2006	ALL	Body	Rear Seat Audio																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2007	ALL	Chassis	Electronic Brake Control Module																																																												
K	2007	ALL	Chassis	Electronic Suspension Control																																																												
K	2007	ALL	Body	Amplifier (Bose)																																																												
K	2007	ALL	Body	Assist Step Controller																																																												
K	2007	ALL	Body	Body Control Module																																																												
K	2007	ALL	Body	Body Control Module (aux.)																																																												
K	2007	ALL	Body	Digital Radio Receiver																																																												
K	2007	ALL	Body	Driver Door Switch																																																												
K	2007	ALL	Body	HVAC Control Module																																																												
K	2007	ALL	Body	Inside Rear View Mirror Module																																																												
K	2007	ALL	Body	Instrument Panel Cluster																																																												
K	2007	ALL	Body	Lift Gate Module																									V	V																																		
K	2007	ALL	Body	Memory Seat Module																																																												
K	2007	ALL	Body	Park Assist Module																																																												
K	2007	ALL	Body	Passenger Door Switch																																																												
K	2007	ALL	Body	Passenger Presence System																																																												
K	2007	ALL	Body	Radio																																																												
K	2007	ALL	Body	Rear Heated Seat Module																																																												
K	2007	ALL	Body	Rear HVAC/RSA																																																												
K	2007	ALL	Body	Rollover Sensor																																																												
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2007	ALL	Body	Theft Deterrent Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2008	ALL	Chassis	Electronic Brake Control Module			V																																																									
K	2008	ALL	Chassis	Electronic Suspension Control																																																												
K	2008	ALL	Chassis	Trailer Brake Control Module																																																												
K	2008	ALL	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2008	ALL	Body	Assist Step Controller																																																													
K	2008	ALL	Body	Body Control Module																																																													
K	2008	ALL	Body	Body Control Module (aux.)																																																												
K	2008	ALL	Body	Digital Radio Receiver																																																												
K	2008	ALL	Body	Driver Door Switch																																																												
K	2008	ALL	Body	HVAC Control Module																																																												
K	2008	ALL	Body	Inside Rear View Mirror Module																																																												
K	2008	ALL	Body	Instrument Panel Cluster																																																												
K	2008	ALL	Body	Lift Gate Module																									V	V																																			
K	2008	ALL	Body	Memory Seat Module																																																												
K	2008	ALL	Body	Park Assist Module																																																												
K	2008	ALL	Body	Passenger Door Switch																																																												
K	2008	ALL	Body	Passenger Presence System																																																												
K	2008	ALL	Body	Radio																																																												
K	2008	ALL	Body	Rear Heated Seat Module																																																												
K	2008	ALL	Body	Rear HVAC/RSA																																																												
K	2008	ALL	Body	Rollover Sensor																																																												
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2008	ALL	Body	Theft Deterrent Module																																																												
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																		
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	ALL	Chassis	Electronic Brake Control Module			V																																																									
K	2009	ALL	Chassis	Electronic Suspension Control																																																												
K	2009	ALL	Chassis	Trailer Brake Control Module																																																												
K	2009	ALL	Body	Amplifier (Bose)																																																												
K	2009	ALL	Body	Assist Step Controller																																																												
K	2009	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2009	ALL	Body	Body Control Module (aux.)																																																												
K	2009	ALL	Body	Digital Radio Receiver																																																												
K	2009	ALL	Body	Driver Door Switch																																																												
K	2009	ALL	Body	HVAC Control Module																																																												
K	2009	ALL	Body	Inside Rear View Mirror Module																																																												
K	2009	ALL	Body	Instrument Panel Cluster																																																												
K	2009	ALL	Body	Left Side Object Detection Module						V																																																						
K	2009	ALL	Body	Lift Gate Module																									V	V																																			
K	2009	ALL	Body	Memory Seat Module																																																												
K	2009	ALL	Body	Park Assist Module																																																												
K	2009	ALL	Body	Passenger Door Switch																																																												
K	2009	ALL	Body	Passenger Presence System																																																												
K	2009	ALL	Body	Radio																																																												
K	2009	ALL	Body	Rear Heated Seat Module																																																												
K	2009	ALL	Body	Rear HVAC/RSA																																																												
K	2009	ALL	Body	Right Side Object Detection Module						V																																																					
K	2009	ALL	Body	Rollover Sensor																																																												
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2009	ALL	Body	Theft Deterrent Module																																																												
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2010	ALL	Chassis	Electronic Brake Control Module			V																																																										
K	2010	ALL	Chassis	Electronic Suspension Control																																																													
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																													
K	2010	ALL	Body	Amplifier (Bose)																																																													
K	2010	ALL	Body	Assist Step Controller																																																													
K	2010	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2010	ALL	Body	Body Control Module (aux.)																																																													
K	2010	ALL	Body	Digital Radio Receiver																																																													
K	2010	ALL	Body	Driver Door Switch																																																													
K	2010	ALL	Body	HVAC Control Module																																																													
K	2010	ALL	Body	Inside Rear View Mirror Module																																																													
K	2010	ALL	Body	Instrument Panel Cluster																																																													
K	2010	ALL	Body	Left Side Object Detection Module						V																																																							
K	2010	ALL	Body	Lift Gate Module																									V	V			V	V																																
K	2010	ALL	Body	Memory Seat Module																																																													
K	2010	ALL	Body	Park Assist Module																																																													
K	2010	ALL	Body	Passenger Door Switch																																																													
K	2010	ALL	Body	Passenger Presence System																																																													
K	2010	ALL	Body	Radio																																																													
K	2010	ALL	Body	Rear Heated Seat Module																																																													
K	2010	ALL	Body	Rear HVAC/RSA																																																													
K	2010	ALL	Body	Right Side Object Detection Module						V																																																							
K	2010	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
K	2010	ALL	Body	Theft Deterrent Module																																																													
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																													
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																													
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																													
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																													
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																													
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																													
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																													
N	2010	SRX	Chassis	Electronic Brake Control Module																																																													
N	2010	SRX	Chassis	Parking Brake Control Module																																																													
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																													
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																																													
N	2010	SRX	Chassis	Suspension Control Module																																																													
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																													
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
N	2010	SRX	Body	Passenger Presence Module																																																													
N	2010	SRX	Body	Instrument Cluster																																																													
N	2010	SRX	Body	Headlamp Control Module																																																													
N	2010	SRX	Body	Trailer Interface Control Module																																																													
N	2010	SRX	Body	Radio																																																													
N	2010	SRX	Body	Rear Audio Control Module																																																													
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																													
N	2010	SRX	Body	Multimedia Player Interface Module																																																													
N	2010	SRX	Body	Mobile Telephone Control Module																																																													
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																													
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																													
N	2010	SRX	Body	Liftgate Control Module																																																				V	V	V	V				
N	2010	SRX	Body	Seat Memory Control Module																																																							V			
N	2010	SRX	Body	Front Seat Heating Control Module																																																												
N	2010	SRX	Body	Rear Seat Heating Control Module																																																												
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																												
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																												
N	2010	SRX	Body	Parking Assist Control Module																																																												
N	2010	SRX	Body	Steering Column Lock Control Module																																																												
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																												
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																												
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																												
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																												
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2011	SRX	Chassis	Electronic Brake Control Module																																																												
N	2011	SRX	Chassis	Parking Brake Control Module																																																												
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2011	SRX	Chassis	Suspension Control Module																																																												
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2011	SRX	Body	Passenger Presence Module																																																												
N	2011	SRX	Body	Instrument Cluster																																																												
N	2011	SRX	Body	Headlamp Control Module																																																												
N	2011	SRX	Body	Trailer Interface Control Module																																																												
N	2011	SRX	Body	Radio																																																												
N	2011	SRX	Body	Rear Audio Control Module																																																												
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																												
N	2011	SRX	Body	Multimedia Player Interface Module																																																												
N	2011	SRX	Body	Mobile Telephone Control Module																																																												
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																												
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																												
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																												
N	2011	SRX	Body	Liftgate Control Module																																																			V	V	V	V				
N	2011	SRX	Body	Seat Memory Control Module																																																												
N	2011	SRX	Body	Front Seat Heating Control Module																																																												
N	2011	SRX	Body	Rear Seat Heating Control Module																																																												
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																												
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																												
N	2011	SRX	Body	Parking Assist Control Module																																																												
N	2011	SRX	Body	Steering Column Lock Control Module																																																												
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																												
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																													
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																													
N	2012	SRX	Chassis	Electronic Brake Control Module																																																													
N	2012	SRX	Chassis	Parking Brake Control Module																																																													
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																													
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																																													
N	2012	SRX	Chassis	Suspension Control Module																																																													
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																													
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
N	2012	SRX	Body	Passenger Presence Module																																																													
N	2012	SRX	Body	Instrument Cluster																																																													
N	2012	SRX	Body	Headlamp Control Module																																																													
N	2012	SRX	Body	Trailer Interface Control Module																																																													
N	2012	SRX	Body	Radio																																																													
N	2012	SRX	Body	Rear Audio Control Module																																																													
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																													
N	2012	SRX	Body	Multimedia Player Interface Module																																																													
N	2012	SRX	Body	Mobile Telephone Control Module																																																													
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																																													
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																																													
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																													
N	2012	SRX	Body	Liftgate Control Module																																																					V	V	V	V		
N	2012	SRX	Body	Seat Memory Control Module																																																													
N	2012	SRX	Body	Front Seat Heating Control Module																																																													
N	2012	SRX	Body	Rear Seat Heating Control Module																																																													
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																													
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																													
N	2012	SRX	Body	Parking Assist Control Module																																																													
N	2012	SRX	Body	Steering Column Lock Control Module																																																													
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																													
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																													
N	2013	SRX	Chassis	Electronic Brake Control Module																																																													
N	2013	SRX	Chassis	Parking Brake Control Module																																																													
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																													
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																																													
N	2013	SRX	Chassis	Suspension Control Module																																																													
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																													
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
N	2013	SRX	Body	Passenger Presence Module																																																													
N	2013	SRX	Body	Instrument Cluster																																																													
N	2013	SRX	Body	Radio/HVAC Control																																																													
N	2013	SRX	Body	Active Safety Control Module																																																													
N	2013	SRX	Body	Headlamp Control Module																																																													
N	2013	SRX	Body	Trailer Interface Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
N	2013	SRX	Body	Radio																																																										
N	2013	SRX	Body	Amplifier																																																										
N	2013	SRX	Body	Media Disc Player																																																										
N	2013	SRX	Body	Human Machine Interface Control Module																																																										
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2013	SRX	Body	Liftgate Control Module																																																					V	V	V	V		
N	2013	SRX	Body	Seat Memory Control Module																																																										
N	2013	SRX	Body	Rear Seat Heating Control Module																																																										
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2013	SRX	Body	Right Side Object Detection Control Module																																																										
N	2013	SRX	Body	Left Side Object Detection Control Module																																																										
N	2013	SRX	Body	Parking Assist Control Module																																																										
N	2013	SRX	Body	Frontview Camera Module																																																										
N	2013	SRX	Body	Steering Column Lock Control Module																																																										
N	2013	SRX	Body	Long Range Radar Sensor Module																																																										
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																										
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2014	SRX	Chassis	Electronic Brake Control Module																																																										
N	2014	SRX	Chassis	Parking Brake Control Module																																																										
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2014	SRX	Chassis	Suspension Control Module																																																										
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2014	SRX	Body	Passenger Presence Module																																																										
N	2014	SRX	Body	Instrument Cluster																																																										
N	2014	SRX	Body	Radio/HVAC Control																																																										
N	2014	SRX	Body	Active Safety Control Module																																																										
N	2014	SRX	Body	Headlamp Control Module																																																										
N	2014	SRX	Body	Trailer Interface Control Module																																																										
N	2014	SRX	Body	Radio																																																										
N	2014	SRX	Body	Amplifier																																																										
N	2014	SRX	Body	Media Disc Player																																																										
N	2014	SRX	Body	Human Machine Interface Control Module																																																										
N	2014	SRX	Body	Navigation Control Module																																																										
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																										
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2014	SRX	Body	Liftgate Control Module																																																					V	V	V	V		

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																														
N	2014	SRX	Body	Rear Seat Heating Control Module																																																														
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																														
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																														
N	2014	SRX	Body	Right Side Object Detection Control Module																																																														
N	2014	SRX	Body	Left Side Object Detection Control Module																																																														
N	2014	SRX	Body	Parking Assist Control Module																																																														
N	2014	SRX	Body	Frontview Camera Module																																																														
N	2014	SRX	Body	Steering Column Lock Control Module																																																														
N	2014	SRX	Body	Long Range Radar Sensor Module																																																														
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																														
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																														
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																														
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																														
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																														
N	2015	SRX	Chassis	Electronic Brake Control Module																																																														
N	2015	SRX	Chassis	Parking Brake Control Module																																																														
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																														
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																																														
N	2015	SRX	Chassis	Suspension Control Module																																																														
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
N	2015	SRX	Body	Passenger Presence Module																																																															
N	2015	SRX	Body	Instrument Cluster																																																															
N	2015	SRX	Body	Radio/HVAC Control																																																															
N	2015	SRX	Body	Active Safety Control Module																																																															
N	2015	SRX	Body	Headlamp Control Module																																																															
N	2015	SRX	Body	Trailer Interface Control Module																																																															
N	2015	SRX	Body	Radio																																																															
N	2015	SRX	Body	Amplifier																																																															
N	2015	SRX	Body	Rear Audio Control Module																																																															
N	2015	SRX	Body	Media Disc Player																																																															
N	2015	SRX	Body	Human Machine Interface Control Module																																																															
N	2015	SRX	Body	Navigation Control Module																																																															
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																															
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																																															
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																															
N	2015	SRX	Body	Liftgate Control Module																																																															
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																															
N	2015	SRX	Body	Rear Seat Heating Control Module																																																															
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																															
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																															
N	2015	SRX	Body	Right Side Object Detection Control Module																																																															
N	2015	SRX	Body	Left Side Object Detection Control Module																																																															
N	2015	SRX	Body	Parking Assist Control Module																																																															
N	2015	SRX	Body	Frontview Camera Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
N	2015	SRX	Body	Steering Column Lock Control Module																																																														
N	2015	SRX	Body	Long Range Radar Sensor Module																																																														
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																													
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																													
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																													
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																													
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																													
N	2016	SRX	Chassis	Electronic Brake Control Module																																																													
N	2016	SRX	Chassis	Parking Brake Control Module																																																													
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																													
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																																													
N	2016	SRX	Chassis	Suspension Control Module																																																													
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																													
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
N	2016	SRX	Body	Passenger Presence Module																																																													
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																													
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																																													
N	2016	SRX	Body	Radio/HVAC Control																																																													
N	2016	SRX	Body	Active Safety Control Module																																																													
N	2016	SRX	Body	Headlamp Control Module																																																													
N	2016	SRX	Body	Trailer Interface Control Module																																																													
N	2016	SRX	Body	Radio																																																													
N	2016	SRX	Body	Amplifier																																																												
N	2016	SRX	Body	Rear Audio Control Module																																																													
N	2016	SRX	Body	Media Disc Player																																																													
N	2016	SRX	Body	Human Machine Interface Control Module																																																													
N	2016	SRX	Body	Navigation Control Module																																																													
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																													
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																																													
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																													
N	2016	SRX	Body	Liftgate Control Module																																																						V	V	V	V		
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																													
N	2016	SRX	Body	Rear Seat Heating Control Module																																																													
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																													
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																													
N	2016	SRX	Body	Right Side Object Detection Control Module																																																													
N	2016	SRX	Body	Left Side Object Detection Control Module																																																													
N	2016	SRX	Body	Parking Assist Control Module																																																													
N	2016	SRX	Body	Frontview Camera Module																																																													
N	2016	SRX	Body	Steering Column Lock Control Module																																																													
N	2016	SRX	Body	Long Range Radar Sensor Module																																																													
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																													
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																													
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																													
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																													
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																													
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
3	2011	ALL	Chassis	Electronic Brake Control Module			V																																																										
3	2011	ALL	Chassis	Electronic Suspension Control																																																													
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																													
3	2011	ALL	Body	Amplifier (Bose)																																																													
3	2011	ALL	Body	Assist Step Controller																																																													
3	2011	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																								
3	2011	ALL	Body	Body Control Module (aux.)																																																													
3	2011	ALL	Body	Digital Radio Receiver																																																													
3	2011	ALL	Body	Driver Door Switch																																																													
3	2011	ALL	Body	HVAC Control Module																																																													
3	2011	ALL	Body	Inside Rear View Mirror Module																																																													
3	2011	ALL	Body	Instrument Panel Cluster																																																													
3	2011	ALL	Body	Left Side Object Detection Module						V																																																							
3	2011	ALL	Body	Lift Gate Module																									V	V			V	V																																
3	2011	ALL	Body	Memory Seat Module																																																													
3	2011	ALL	Body	Park Assist Module																																																													
3	2011	ALL	Body	Passenger Door Switch																																																													
3	2011	ALL	Body	Passenger Presence System																																																													
3	2011	ALL	Body	Radio																																																													
3	2011	ALL	Body	Rear Heated Seat Module																																																													
3	2011	ALL	Body	Rear HVAC/RSA																																																													
3	2011	ALL	Body	Right Side Object Detection Module						V																																																							
3	2011	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
3	2011	ALL	Body	Theft Deterrent Module																																																													
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																														
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																														
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
3	2012	ALL	Chassis	Electronic Brake Control Module			V																																																										
3	2012	ALL	Chassis	Electronic Suspension Control																																																													
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																													
3	2012	ALL	Body	Amplifier (Bose)																																																													
3	2012	ALL	Body	Assist Step Controller																																																													
3	2012	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
3	2012	ALL	Body	Body Control Module (aux.)																																																													
3	2012	ALL	Body	Driver Door Switch																																																													
3	2012	ALL	Body	HVAC Control Module																																																													
3	2012	ALL	Body	Inside Rear View Mirror Module																																																													
3	2012	ALL	Body	Instrument Panel Cluster																																																													
3	2012	ALL	Body	Left Side Object Detection Module						V																																																							
3	2012	ALL	Body	Lift Gate Module																									V	V			V	V																																
3	2012	ALL	Body	Memory Seat Module																																																													
3	2012	ALL	Body	Park Assist Module																																																													
3	2012	ALL	Body	Passenger Door Switch																																																													
3	2012	ALL	Body	Passenger Presence System																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
3	2012	ALL	Body	Radio																																																										
3	2012	ALL	Body	Rear Heated Seat Module																																																										
3	2012	ALL	Body	Rear HVAC/RSA																																																										
3	2012	ALL	Body	Right Side Object Detection Module						V																																																				
3	2012	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
3	2012	ALL	Body	Theft Deterrent Module																																																										
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
3	2013	ALL	Chassis	Electronic Brake Control Module			V																																																							
3	2013	ALL	Chassis	Electronic Suspension Control																																																										
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2013	ALL	Body	Amplifier (Bose)																																																										
3	2013	ALL	Body	Assist Step Controller																																																										
3	2013	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																					
3	2013	ALL	Body	Body Control Module (aux.)																																																										
3	2013	ALL	Body	Driver Door Switch																																																										
3	2013	ALL	Body	HVAC Control Module																																																										
3	2013	ALL	Body	Inside Rear View Mirror Module																																																										
3	2013	ALL	Body	Instrument Panel Cluster																																																										
3	2013	ALL	Body	Left Side Object Detection Module						V																																																				
3	2013	ALL	Body	Lift Gate Module																									V	V			V	V																												
3	2013	ALL	Body	Memory Seat Module																																																										
3	2013	ALL	Body	Park Assist Module																																																										
3	2013	ALL	Body	Passenger Door Switch																																																										
3	2013	ALL	Body	Passenger Presence System																																																										
3	2013	ALL	Body	Radio																																																										
3	2013	ALL	Body	Rear Heated Seat Module																																																										
3	2013	ALL	Body	Rear HVAC/RSA																																																										
3	2013	ALL	Body	Right Side Object Detection Module						V																																																				
3	2013	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
3	2013	ALL	Body	Theft Deterrent Module																																																										
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																										
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2014	Escalade	Chassis	Suspension Control Module																																																										
3	2014	Escalade	Body	Body Control Module																																			V	V	V	V	V	V	V	V	V	V														
3	2014	Escalade	Body	Auxiliary Body Control Module																																																										
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2014	Escalade	Body	Passenger Presence Module																																																										
3	2014	Escalade	Body	Instrument Cluster																																																										
3	2014	Escalade	Body	Radio																																																										
3	2014	Escalade	Body	Amplifier																																																										
3	2014	Escalade	Body	Rear Audio Control Module																																																										
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																										
3	2014	Escalade	Body	Personal Audio Link Control Module																																																										
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																										
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
3	2014	Escalade	Body	HVAC Control Module																																																	V								
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																									
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																									
3	2014	Escalade	Body	Liftgate Control Module																																																			V	V	V	V		
3	2014	Escalade	Body	Seat Memory Control Module																																																							V	V
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																								
3	2014	Escalade	Body	Assist Step Control Module																																																								
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																								
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																								
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																								
3	2014	Escalade	Body	Parking Assist Control Module																																																								
3	2014	Escalade	Body	Theft Deterrent Module																																																								
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																								
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																								
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																								
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																								
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																								
3	2014	Escalade ESV	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V											
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																								
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
3	2014	Escalade ESV	Body	Passenger Presence Module																																																	V								
3	2014	Escalade ESV	Body	Instrument Cluster																																																								
3	2014	Escalade ESV	Body	Radio																																																								
3	2014	Escalade ESV	Body	Amplifier																																																								
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																								
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																								
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																								
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																								
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																								
3	2014	Escalade ESV	Body	HVAC Control Module																																																	V								
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																								
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																								
3	2014	Escalade ESV	Body	Liftgate Control Module																																																			V	V	V	V		
3	2014	Escalade ESV	Body	Seat Memory Control Module																																																							V	V
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																								
3	2014	Escalade ESV	Body	Assist Step Control Module																																																								
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																								
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																								
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																								
3	2014	Escalade ESV	Body	Parking Assist Control Module																																																								
3	2014	Escalade ESV	Body	Theft Deterrent Module																																																								
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																								
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																								
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																														
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																														
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																														
3	2015	Escalade	Chassis	Electronic Brake Control Module																																																													
3	2015	Escalade	Chassis	Parking Brake Control Module																																																													
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																													
3	2015	Escalade	Chassis	Power Steering Control Module																																																													
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																													
3	2015	Escalade	Chassis	Suspension Control Module																																																													
3	2015	Escalade	Body	Body Control Module																																																													
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
3	2015	Escalade	Body	Passenger Presence Module																																																													
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																													
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																													
3	2015	Escalade	Body	Instrument Cluster																																																													
3	2015	Escalade	Body	Radio/HVAC Control																																																													
3	2015	Escalade	Body	Active Safety Control Module																																																													
3	2015	Escalade	Body	Video Processing Control Module																																																													
3	2015	Escalade	Body	Radio																																																													
3	2015	Escalade	Body	Amplifier																																																													
3	2015	Escalade	Body	Media Disc Player																																																													
3	2015	Escalade	Body	Human Machine Interface Control Module																																																													
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																													
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																													
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																													
3	2015	Escalade	Body	HVAC Control Module																																																													
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																															V	V																	V	V	V	V		
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																															V	V																	V	V	V	V		
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																												
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																												
3	2015	Escalade	Body	Keyless Entry Control Module																																																												
3	2015	Escalade	Body	Assist Step Control Module																																																												
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																												
3	2015	Escalade	Body	Parking Assist Control Module																																																												
3	2015	Escalade	Body	Frontview Camera Module																																																												
3	2015	Escalade	Body	Steering Column Lock Control Module																																																												
3	2015	Escalade	Body	Battery Energy Control Module																																																												
3	2015	Escalade	Body	Long Range Radar Sensor Module																																																												
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																												
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																												
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																												
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																												
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																											
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																											
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																												
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																												
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																												
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																																												
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																												
3	2015	Escalade ESV	Chassis	Suspension Control Module																																																												
3	2015	Escalade ESV	Body	Body Control Module																																																												
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
3	2015	Escalade ESV	Body	Passenger Presence Module																																																												
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																												
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																												
3	2015	Escalade ESV	Body	Instrument Cluster																																																												
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																												
3	2015	Escalade ESV	Body	Active Safety Control Module																																																												
3	2015	Escalade ESV	Body	Video Processing Control Module																																																												
3	2015	Escalade ESV	Body	Radio																																																												
3	2015	Escalade ESV	Body	Amplifier																																																												
3	2015	Escalade ESV	Body	Media Disc Player																																																												
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																												
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																												
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																												
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																												
3	2015	Escalade ESV	Body	HVAC Control Module																																																												
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																					V	V	V	V		
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																				V	V	V	V		
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																												
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																												
3	2015	Escalade ESV	Body	Assist Step Control Module																																																												
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																												
3	2015	Escalade ESV	Body	Parking Assist Control Module																																																												
3	2015	Escalade ESV	Body	Frontview Camera Module																																																												
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																												
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																												
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																												
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																												
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																												
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																												
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
3	2016	Escalade	Chassis	Electronic Brake Control Module																																																												
3	2016	Escalade	Chassis	Parking Brake Control Module																																																												
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																												
3	2016	Escalade	Chassis	Power Steering Control Module																																																												
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																												
3	2016	Escalade	Chassis	Suspension Control Module																																																												
3	2016	Escalade	Body	Body Control Module																																																												
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
3	2016	Escalade	Body	Passenger Presence Module																																																														
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																													
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																													
3	2016	Escalade	Body	Instrument Cluster																																																													
3	2016	Escalade	Body	Radio/HVAC Control																																																													
3	2016	Escalade	Body	Active Safety Control Module																																																													
3	2016	Escalade	Body	Video Processing Control Module																																																													
3	2016	Escalade	Body	Radio																																																													
3	2016	Escalade	Body	Amplifier																																																													
3	2016	Escalade	Body	Media Disc Player																																																													
3	2016	Escalade	Body	Human Machine Interface Control Module																																																													
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																																													
3	2016	Escalade	Body	HVAC Control Module																																																													
3	2016	Escalade	Body	Liftgate Control Module																																																						V	V	V	V			
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																													
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																													
3	2016	Escalade	Body	Keyless Entry Control Module																																																													
3	2016	Escalade	Body	Assist Step Control Module																																																													
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																													
3	2016	Escalade	Body	Parking Assist Control Module																																																													
3	2016	Escalade	Body	Frontview Camera Module																																																													
3	2016	Escalade	Body	Steering Column Lock Control Module																																																													
3	2016	Escalade	Body	Long Range Radar Sensor Module																																																													
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																													
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																													
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																													
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																													
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																													
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																													
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																													
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																													
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																													
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																																													
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																													
3	2016	Escalade ESV	Chassis	Suspension Control Module																																																													
3	2016	Escalade ESV	Body	Body Control Module																																																													
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
3	2016	Escalade ESV	Body	Passenger Presence Module																																																													
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																													
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																													
3	2016	Escalade ESV	Body	Instrument Cluster																																																													
3	2016	Escalade ESV	Body	Radio Control																																																													
3	2016	Escalade ESV	Body	HVAC Control																																																													
3	2016	Escalade ESV	Body	Active Safety Control Module																																																													
3	2016	Escalade ESV	Body	Video Processing Control Module																																																													
3	2016	Escalade ESV	Body	Radio																																																													
3	2016	Escalade ESV	Body	Amplifier																																																													
3	2016	Escalade ESV	Body	Media Disc Player																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																														
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																														
3	2016	Escalade ESV	Body	HVAC Control Module																																																														
3	2016	Escalade ESV	Body	Liftgate Control Module																																																						V	V	V	V			
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																														
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																														
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																														
3	2016	Escalade ESV	Body	Assist Step Control Module																																																														
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																														
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																														
3	2016	Escalade ESV	Body	Frontview Camera Module																																																														
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																														
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																														
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																														
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																														
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																														
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																														
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																														
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																														
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
4	2011	ALL	Chassis	Electronic Brake Control Module			V																																																											
4	2011	ALL	Chassis	Electronic Suspension Control																																																														
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																														
4	2011	ALL	Body	Amplifier (Bose)																																																														
4	2011	ALL	Body	Assist Step Controller																																																														
4	2011	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																								
4	2011	ALL	Body	Body Control Module (aux.)																																																														
4	2011	ALL	Body	Driver Door Switch																																																														
4	2011	ALL	Body	HVAC Control Module																																																														
4	2011	ALL	Body	Inside Rear View Mirror Module																																																														
4	2011	ALL	Body	Instrument Panel Cluster																																																														
4	2011	ALL	Body	Left Side Object Detection Module						V																																																							
4	2011	ALL	Body	Lift Gate Module																									V	V			V	V																																
4	2011	ALL	Body	Memory Seat Module																																																														
4	2011	ALL	Body	Park Assist Module																																																														
4	2011	ALL	Body	Passenger Door Switch																																																														
4	2011	ALL	Body	Passenger Presence System																																																														
4	2011	ALL	Body	Radio																																																														
4	2011	ALL	Body	Rear Heated Seat Module																																																														
4	2011	ALL	Body	Rear HVAC/RSA																																																														
4	2011	ALL	Body	Right Side Object Detection Module						V																																																							
4	2011	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
4	2011	ALL	Body	Theft Deterrent Module																																																														
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																														
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																														
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
4	2012	ALL	Chassis	Electronic Brake Control Module			V																																																										
4	2012	ALL	Chassis	Electronic Suspension Control																																																													
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																													
4	2012	ALL	Body	Amplifier (Bose)																																																													
4	2012	ALL	Body	Assist Step Controller																																																													
4	2012	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																								
4	2012	ALL	Body	Body Control Module (aux.)																																																													
4	2012	ALL	Body	Driver Door Switch																																																													
4	2012	ALL	Body	HVAC Control Module																																																													
4	2012	ALL	Body	Inside Rear View Mirror Module																																																													
4	2012	ALL	Body	Instrument Panel Cluster																																																													
4	2012	ALL	Body	Left Side Object Detection Module						V																																																							
4	2012	ALL	Body	Lift Gate Module																									V	V			V	V																																
4	2012	ALL	Body	Memory Seat Module																																																													
4	2012	ALL	Body	Park Assist Module																																																													
4	2012	ALL	Body	Passenger Door Switch																																																													
4	2012	ALL	Body	Passenger Presence System																																																													
4	2012	ALL	Body	Radio																																																													
4	2012	ALL	Body	Rear Heated Seat Module																																																													
4	2012	ALL	Body	Rear HVAC/RSA																																																													
4	2012	ALL	Body	Right Side Object Detection Module						V																																																							
4	2012	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
4	2012	ALL	Body	Theft Deterrent Module																																																													
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																														
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																													
4	2013	ALL	Chassis	Electronic Brake Control Module			V																																																										
4	2013	ALL	Chassis	Electronic Suspension Control																																																													
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																													
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																													
4	2013	ALL	Body	Amplifier (Bose)																																																													
4	2013	ALL	Body	Assist Step Controller																																																													
4	2013	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																								
4	2013	ALL	Body	Body Control Module (aux.)																																																													
4	2013	ALL	Body	Driver Door Switch																																																													
4	2013	ALL	Body	HVAC Control Module																																																													
4	2013	ALL	Body	Inside Rear View Mirror Module																																																													
4	2013	ALL	Body	Instrument Panel Cluster																																																													
4	2013	ALL	Body	Left Side Object Detection Module						V																																																							
4	2013	ALL	Body	Lift Gate Module																									V	V			V	V																																
4	2013	ALL	Body	Memory Seat Module																																																													
4	2013	ALL	Body	Park Assist Module																																																													
4	2013	ALL	Body	Passenger Door Switch																																																													
4	2013	ALL	Body	Passenger Presence System																																																													
4	2013	ALL	Body	Radio																																																													
4	2013	ALL	Body	Rear Heated Seat Module																																																													
4	2013	ALL	Body	Rear HVAC/RSA																																																													
4	2013	ALL	Body	Right Side Object Detection Module						V																																																							
4	2013	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
4	2013	ALL	Body	Theft Deterrent Module																																																													

| Engine type | Year | Model | System 1 | System 2 | New Actuator Setup Procedure | VSCM Data | Signal Data | VSCM Disable Reason | VSCM Power Steering Reset | Range Measurements | Module Data | Inhibit Data | Calibrate Module | Exh. Aftertreatment Data | Parking Brake Shoe Service Reset | Parking Brake Actuator DTC Reset | Parking Brake Switch Procedure | Charging Info | RVS Disable 1 History | RVS Disable 2 History | RVS Disable 3 History | RVS Disable 4 History | RVS Disable 5 History | RVS Disable 6 History | RVS Disable 7 History | Passenger presence system learn | Signal Type | Module ID Information | Open History Data | Close History Data | Last Open Fail Data | Last Close Fail Data | Obstacle Detect Opening Data | Obstacle Detect Closing Data | LGM Open/Close Test | Deployment Loop 1-14 Resistance | Deployment Loop 15-18 Resistance | Deployment Loop Configuration | Sensor Configuration | Parking Brake Calibration | CAN Bus Communication | Remote Vehicle Start Data | Remote Vehicle Start Disable History 1 Data | Remote Vehicle Start Disable History 2 Data | Remote Vehicle Start Disable History 3 Data | Remote Vehicle Start Disable History 4 Data | Remote Vehicle Start Disable History 5 Data | Remote Vehicle Start Disable History 6 Data | Remote Vehicle Start Disable History 7 Data | Steering Wheel Control Switches | Vehicle Access | Passenger Presence Data | HVAC Door Position Data | A/C Permission Data | Last Liftgate Close Malfunction Data | Last Liftgate Open Malfunction Data | Engineering Data 1 | Engineering Data 2 | Seat Position Data | Steering Column Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | New Actuator Setup Procedure | VSCM Data | Signal Data | VSCM Disable Reason | VSCM Power Steering Reset | Range Measurements | Module Data | Inhibit Data | Calibrate Module | Exh. Aftertreatment Data | Parking Brake Shoe Service Reset | Parking Brake Actuator DTC Reset | Parking Brake Switch Procedure | Charging Info | RVS Disable 1 History | RVS Disable 2 History | RVS Disable 3 History | RVS Disable 4 History | RVS Disable 5 History | RVS Disable 6 History | RVS Disable 7 History | Passenger presence system learn | Signal Type | Module ID Information | Open History Data | Close History Data | Last Open Fail Data | Last Close Fail Data | Obstacle Detect Opening Data | Obstacle Detect Closing Data | LGM Open/Close Test | Deployment Loop 1-14 Resistance | Deployment Loop 15-18 Resistance | Deployment Loop Configuration | Sensor Configuration | Parking Brake Calibration | CAN Bus Communication | Remote Vehicle Start Data | Remote Vehicle Start Disable History 1 Data | Remote Vehicle Start Disable History 2 Data | Remote Vehicle Start Disable History 3 Data | Remote Vehicle Start Disable History 4 Data | Remote Vehicle Start Disable History 5 Data | Remote Vehicle Start Disable History 6 Data | Remote Vehicle Start Disable History 7 Data | Steering Wheel Control Switches | Vehicle Access | Passenger Presence Data | HVAC Door Position Data | A/C Permission Data | Last Liftgate Close Malfunction Data | Last Liftgate Open Malfunction Data | Engineering Data 1 | Engineering Data 2 | Seat Position Data | Steering Column Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
4	2015	Escalade	Body	Parking Assist Control Module																																																															
4	2015	Escalade	Body	Frontview Camera Module																																																														
4	2015	Escalade	Body	Steering Column Lock Control Module																																																														
4	2015	Escalade	Body	Battery Energy Control Module																																																														
4	2015	Escalade	Body	Long Range Radar Sensor Module																																																														
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																														
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																														
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																														
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																														
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																														
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																														
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																														
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																														
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																														
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																														
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																														
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																														
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																														
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																																														
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																														
4	2015	Escalade ESV	Chassis	Suspension Control Module																																																														
4	2015	Escalade ESV	Body	Body Control Module																																																														
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
4	2015	Escalade ESV	Body	Passenger Presence Module																																																														
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																														
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																														
4	2015	Escalade ESV	Body	Instrument Cluster																																																														
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																														
4	2015	Escalade ESV	Body	Active Safety Control Module																																																														
4	2015	Escalade ESV	Body	Video Processing Control Module																																																														
4	2015	Escalade ESV	Body	Radio																																																														
4	2015	Escalade ESV	Body	Amplifier																																																														
4	2015	Escalade ESV	Body	Media Disc Player																																																														
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																														
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																														
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																														
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																														
4	2015	Escalade ESV	Body	HVAC Control Module																																																														
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																														
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																														
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																														
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																														
4	2015	Escalade ESV	Body	Assist Step Control Module																																																														
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																														
4	2015	Escalade ESV	Body	Parking Assist Control Module																																																														
4	2015	Escalade ESV	Body	Frontview Camera Module																																																														
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																														
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																														
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																														
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																														
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																														
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																														
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																														
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
4	2016	Escalade	Chassis	Electronic Brake Control Module																																																														
4	2016	Escalade	Chassis	Parking Brake Control Module																																																														
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																														
4	2016	Escalade	Chassis	Power Steering Control Module																																																														
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																														
4	2016	Escalade	Chassis	Suspension Control Module																																																														
4	2016	Escalade	Body	Body Control Module																																																														
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
4	2016	Escalade	Body	Passenger Presence Module																																																														
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																														
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																														
4	2016	Escalade	Body	Instrument Cluster																																																														
4	2016	Escalade	Body	Radio/HVAC Control																																																														
4	2016	Escalade	Body	Active Safety Control Module																																																														
4	2016	Escalade	Body	Video Processing Control Module																																																														
4	2016	Escalade	Body	Radio																																																														
4	2016	Escalade	Body	Amplifier																																																														
4	2016	Escalade	Body	Media Disc Player																																																														
4	2016	Escalade	Body	Human Machine Interface Control Module																																																														
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																																														
4	2016	Escalade	Body	HVAC Control Module																																																														
4	2016	Escalade	Body	Liftgate Control Module																																																														
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																														
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																														
4	2016	Escalade	Body	Keyless Entry Control Module																																																														
4	2016	Escalade	Body	Assist Step Control Module																																																														
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																														
4	2016	Escalade	Body	Parking Assist Control Module																																																														
4	2016	Escalade	Body	Frontview Camera Module																																																														
4	2016	Escalade	Body	Steering Column Lock Control Module																																																														
4	2016	Escalade	Body	Long Range Radar Sensor Module																																																														
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																														
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																														
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																														
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																														
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																														
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																														
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																													
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																													
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																																													
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																													
4	2016	Escalade ESV	Chassis	Suspension Control Module																																																													
4	2016	Escalade ESV	Body	Body Control Module																																																													
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
4	2016	Escalade ESV	Body	Passenger Presence Module																																																													
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																													
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																													
4	2016	Escalade ESV	Body	Instrument Cluster																																																													
4	2016	Escalade ESV	Body	Radio Control																																																													
4	2016	Escalade ESV	Body	HVAC Control																																																													
4	2016	Escalade ESV	Body	Active Safety Control Module																																																													
4	2016	Escalade ESV	Body	Video Processing Control Module																																																													
4	2016	Escalade ESV	Body	Radio																																																													
4	2016	Escalade ESV	Body	Amplifier																																																													
4	2016	Escalade ESV	Body	Media Disc Player																																																													
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																													
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																													
4	2016	Escalade ESV	Body	HVAC Control Module																																																													
4	2016	Escalade ESV	Body	Liftgate Control Module																																																							V	V	V	V			
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																													
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																													
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																													
4	2016	Escalade ESV	Body	Assist Step Control Module																																																													
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																													
4	2016	Escalade ESV	Body	Parking Assist Control Module																																																													
4	2016	Escalade ESV	Body	Frontview Camera Module																																																													
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																													
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																													
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																													
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																													
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																													
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																													
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																													
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																													
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																													
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																													
ALL	2004	Hearse	Chassis	DRP/ABS/TCS																																																													
ALL	2004	Hearse	Chassis	Magna Steer																																																													
ALL	2004	Hearse	Chassis	Rear Integration Module																																																													
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																													
ALL	2004	Hearse	Body	Amplifier (Delco)																																																													
ALL	2004	Hearse	Body	Dash Integration Module																																																													
ALL	2004	Hearse	Body	Driver Door Switch																																																													
ALL	2004	Hearse	Body	Driver Door Module																																																													
ALL	2004	Hearse	Body	Passenger Door Module																																																													
ALL	2004	Hearse	Body	Instrument Panel Cluster																																																													
ALL	2004	Hearse	Body	Instrument Panel Module																																																													
ALL	2004	Hearse	Body	Personalization																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
ALL	2004	Hearse	Body	Radio																																																											
ALL	2004	Hearse	Body	Rear Integration Module																																																											
ALL	2004	Hearse	Body	Remote Function Actuation																																																											
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																																																											
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																																											
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																											
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																											
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																											
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																											
ALL	2004	Limousine	Chassis	DRP/ABS/TCS																																																												
ALL	2004	Limousine	Chassis	Magna Steer																																																												
ALL	2004	Limousine	Chassis	Rear Integration Module																																																												
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																												
ALL	2004	Limousine	Body	Amplifier (Delco)																																																												
ALL	2004	Limousine	Body	Dash Integration Module																																																												
ALL	2004	Limousine	Body	Driver Door Switch																																																												
ALL	2004	Limousine	Body	Driver Door Module																																																												
ALL	2004	Limousine	Body	Passenger Door Module																																																												
ALL	2004	Limousine	Body	Left Mid Door Module																																																												
ALL	2004	Limousine	Body	Left Rear Door Module																																																												
ALL	2004	Limousine	Body	Right Mid Door Module																																																												
ALL	2004	Limousine	Body	Right Rear Door Module																																																												
ALL	2004	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2004	Limousine	Body	Instrument Panel Module																																																												
ALL	2004	Limousine	Body	Memory Seat Module																																																												
ALL	2004	Limousine	Body	Navigation Radio																																																												
ALL	2004	Limousine	Body	Personalization																																																												
ALL	2004	Limousine	Body	Radio																																																												
ALL	2004	Limousine	Body	Rear Climate Control Panel																																																												
ALL	2004	Limousine	Body	Rear Integration Module																																																												
ALL	2004	Limousine	Body	Remote Function Actuation																																																												
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																																												
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																												
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																											
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																											
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																											
ALL	2005	Hearse	Chassis	DRP/ABS/TCS																																																											
ALL	2005	Hearse	Chassis	Magna Steer																																																											
ALL	2005	Hearse	Chassis	Rear Integration Module																																																											
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																											
ALL	2005	Hearse	Body	Amplifier (Delco)																																																											
ALL	2005	Hearse	Body	Dash Integration Module																																																											
ALL	2005	Hearse	Body	Driver Door Switch																																																											
ALL	2005	Hearse	Body	Driver Door Module																																																											
ALL	2005	Hearse	Body	Passenger Door Module																																																											
ALL	2005	Hearse	Body	Instrument Panel Cluster																																																											
ALL	2005	Hearse	Body	Instrument Panel Module																																																											
ALL	2005	Hearse	Body	Personalization																																																											
ALL	2005	Hearse	Body	Radio																																																											
ALL	2005	Hearse	Body	Rear Integration Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
ALL	2005	Hearse	Body	Remote Function Actuation																																																												
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																																												
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																												
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																												
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																												
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																												
ALL	2005	Limousine	Chassis	DRP/ABS/TCS																																																												
ALL	2005	Limousine	Chassis	Magna Steer																																																												
ALL	2005	Limousine	Chassis	Rear Integration Module																																																												
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																												
ALL	2005	Limousine	Body	Amplifier (Delco)																																																												
ALL	2005	Limousine	Body	Dash Integration Module																																																												
ALL	2005	Limousine	Body	Driver Door Switch																																																												
ALL	2005	Limousine	Body	Driver Door Module																																																												
ALL	2005	Limousine	Body	Passenger Door Module																																																												
ALL	2005	Limousine	Body	Left Mid Door Module																																																												
ALL	2005	Limousine	Body	Left Rear Door Module																																																												
ALL	2005	Limousine	Body	Right Mid Door Module																																																												
ALL	2005	Limousine	Body	Right Rear Door Module																																																												
ALL	2005	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2005	Limousine	Body	Instrument Panel Module																																																												
ALL	2005	Limousine	Body	Memory Seat Module																																																												
ALL	2005	Limousine	Body	Navigation Radio																																																												
ALL	2005	Limousine	Body	Personalization																																																												
ALL	2005	Limousine	Body	Radio																																																												
ALL	2005	Limousine	Body	Rear Climate Control Panel																																																												
ALL	2005	Limousine	Body	Rear Integration Module																																																												
ALL	2005	Limousine	Body	Remote Function Actuation																																																												
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																																												
ALL	2006	Hearse	Powertrain	Engine Control Module																																																												
ALL	2006	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2006	Hearse	Body	Amplifier (Bose)																																																												
ALL	2006	Hearse	Body	Body Control Module																																																												
ALL	2006	Hearse	Body	Digital Radio Receiver																																																												
ALL	2006	Hearse	Body	Driver Door Switch																																																												
ALL	2006	Hearse	Body	Driver Position Module																																																												
ALL	2006	Hearse	Body	HVAC Control Module																																																												
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																												
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2006	Hearse	Body	Passenger Door Switch																																																												
ALL	2006	Hearse	Body	Passenger Presence System																																																												
ALL	2006	Hearse	Body	Radio																																																												
ALL	2006	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																												
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2006	Hearse	Body	Theft Deterrent Module																																																												
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																								V																																				

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
ALL	2006	Limousine	Powertrain	Engine Control Module																																																											
ALL	2006	Limousine	Powertrain	Transmission Control Module																																																											
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																																											
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																											
ALL	2006	Limousine	Body	Amplifier (Bose)																																																											
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																											
ALL	2006	Limousine	Body	Body Control Module																																																											
ALL	2006	Limousine	Body	Digital Radio Receiver																																																											
ALL	2006	Limousine	Body	Driver Door Switch																																																											
ALL	2006	Limousine	Body	Driver Position Module																																																											
ALL	2006	Limousine	Body	HVAC Control Module																																																											
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																											
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2006	Limousine	Body	Passenger Door Switch																																																											
ALL	2006	Limousine	Body	Passenger Presence System																																																											
ALL	2006	Limousine	Body	Radio																																																											
ALL	2006	Limousine	Body	Rear Heated Seat Module																																																											
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																											
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																																											
ALL	2006	Limousine	Body	Theft Deterrent Module																																																											
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																								V																																			
ALL	2007	Hearse	Powertrain	Engine Control Module																																																											
ALL	2007	Hearse	Powertrain	Transmission Control Module																																																											
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																											
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																																											
ALL	2007	Hearse	Body	Amplifier (Bose)																																																											
ALL	2007	Hearse	Body	Body Control Module																																																											
ALL	2007	Hearse	Body	Digital Radio Receiver																																																											
ALL	2007	Hearse	Body	Driver Door Switch																																																											
ALL	2007	Hearse	Body	Driver Position Module																																																											
ALL	2007	Hearse	Body	HVAC Control Module																																																											
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																											
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																											
ALL	2007	Hearse	Body	Passenger Door Switch																																																											
ALL	2007	Hearse	Body	Passenger Presence System																																																											
ALL	2007	Hearse	Body	Radio																																																											
ALL	2007	Hearse	Body	Rear Heated Seat Module																																																											
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																																											
ALL	2007	Hearse	Body	Theft Deterrent Module																																																											
ALL	2007	Limousine	Powertrain	Engine Control Module																																																											
ALL	2007	Limousine	Powertrain	Transmission Control Module																																																											
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																											
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																																											
ALL	2007	Limousine	Body	Amplifier (Bose)																																																											
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																																											
ALL	2007	Limousine	Body	Body Control Module																																																											
ALL	2007	Limousine	Body	Digital Radio Receiver																																																											
ALL	2007	Limousine	Body	Driver Door Switch																																																											
ALL	2007	Limousine	Body	Driver Position Module																																																											
ALL	2007	Limousine	Body	HVAC Control Module																																																											
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																														
ALL	2007	Limousine	Body	Passenger Door Switch																																																													
ALL	2007	Limousine	Body	Passenger Presence System																																																													
ALL	2007	Limousine	Body	Radio																																																													
ALL	2007	Limousine	Body	Rear Heated Seat Module																																																													
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																																													
ALL	2007	Limousine	Body	Theft Deterrent Module																																																													
ALL	2008	Hearse	Powertrain	Engine Control Module																																																													
ALL	2008	Hearse	Powertrain	Transmission Control Module																																																													
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																													
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																																													
ALL	2008	Hearse	Body	Amplifier (Bose)																																																													
ALL	2008	Hearse	Body	Body Control Module																																																													
ALL	2008	Hearse	Body	Climate Control Seat Module																																																													
ALL	2008	Hearse	Body	Digital Radio Receiver																																																													
ALL	2008	Hearse	Body	Driver Door Switch																																																													
ALL	2008	Hearse	Body	Driver Position Module																																																													
ALL	2008	Hearse	Body	HVAC Control Module																																																													
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																													
ALL	2008	Hearse	Body	Passenger Door Switch																																																													
ALL	2008	Hearse	Body	Passenger Presence System																																																													
ALL	2008	Hearse	Body	Radio																																																													
ALL	2008	Hearse	Body	Rear Heated Seat Module																																																													
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																																													
ALL	2008	Hearse	Body	Theft Deterrent Module																																																													
ALL	2008	Limousine	Powertrain	Engine Control Module																																																													
ALL	2008	Limousine	Powertrain	Transmission Control Module																																																													
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																													
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																																													
ALL	2008	Limousine	Body	Amplifier (Bose)																																																													
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																													
ALL	2008	Limousine	Body	Body Control Module																																																													
ALL	2008	Limousine	Body	Climate Control Seat Module																																																													
ALL	2008	Limousine	Body	Digital Radio Receiver																																																													
ALL	2008	Limousine	Body	Driver Door Switch																																																													
ALL	2008	Limousine	Body	Driver Position Module																																																													
ALL	2008	Limousine	Body	HVAC Control Module																																																													
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																													
ALL	2008	Limousine	Body	Passenger Door Switch																																																													
ALL	2008	Limousine	Body	Passenger Presence System																																																													
ALL	2008	Limousine	Body	Radio																																																													
ALL	2008	Limousine	Body	Rear Heated Seat Module																																																													
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																																													
ALL	2008	Limousine	Body	Theft Deterrent Module																																																													
ALL	2009	Hearse	Powertrain	Engine Control Module										V																																																		
ALL	2009	Hearse	Powertrain	Transmission Control Module																																																													
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																													
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																																													
ALL	2009	Hearse	Body	Amplifier (Bose)																																																													
ALL	2009	Hearse	Body	Body Control Module															V	V	V	V	V	V	V																																							
ALL	2009	Hearse	Body	Climate Control Seat Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
ALL	2009	Hearse	Body	Digital Radio Receiver																																																															
ALL	2009	Hearse	Body	Driver Door Switch																																																															
ALL	2009	Hearse	Body	Driver Position Module																																																															
ALL	2009	Hearse	Body	HVAC Control Module																																																															
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																															
ALL	2009	Hearse	Body	Passenger Door Switch																																																															
ALL	2009	Hearse	Body	Passenger Presence System																																																															
ALL	2009	Hearse	Body	Radio																																																															
ALL	2009	Hearse	Body	Rear Heated Seat Module																																																															
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																																															
ALL	2009	Hearse	Body	Theft Deterrent Module																																																															
ALL	2009	Limousine	Powertrain	Engine Control Module										V																																																				
ALL	2009	Limousine	Powertrain	Transmission Control Module																																																															
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																															
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																																															
ALL	2009	Limousine	Body	Amplifier (Bose)																																																															
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																															
ALL	2009	Limousine	Body	Body Control Module															V	V	V	V	V	V	V																																										
ALL	2009	Limousine	Body	Climate Control Seat Module																																																															
ALL	2009	Limousine	Body	Digital Radio Receiver																																																															
ALL	2009	Limousine	Body	Driver Door Switch																																																															
ALL	2009	Limousine	Body	Driver Position Module																																																															
ALL	2009	Limousine	Body	HVAC Control Module																																																															
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																															
ALL	2009	Limousine	Body	Passenger Door Switch																																																															
ALL	2009	Limousine	Body	Passenger Presence System																																																															
ALL	2009	Limousine	Body	Radio																																																															
ALL	2009	Limousine	Body	Rear Heated Seat Module																																																															
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																																															
ALL	2009	Limousine	Body	Theft Deterrent Module																																																															
ALL	2010	Hearse	Powertrain	Engine Control Module										V																																																				
ALL	2010	Hearse	Powertrain	Transmission Control Module																																																															
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																															
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																																															
ALL	2010	Hearse	Body	Amplifier (Bose)																																																															
ALL	2010	Hearse	Body	Body Control Module															V	V	V	V	V	V	V																																									
ALL	2010	Hearse	Body	Climate Control Seat Module																																																															
ALL	2010	Hearse	Body	Digital Radio Receiver																																																															
ALL	2010	Hearse	Body	Driver Door Switch																																																															
ALL	2010	Hearse	Body	Driver Position Module																																																															
ALL	2010	Hearse	Body	HVAC Control Module																																																															
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																															
ALL	2010	Hearse	Body	Passenger Door Switch																																																															
ALL	2010	Hearse	Body	Passenger Presence System																																																															
ALL	2010	Hearse	Body	Radio																																																															
ALL	2010	Hearse	Body	Rear Heated Seat Module																																																															
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																																															
ALL	2010	Hearse	Body	Theft Deterrent Module																																																															
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																								V																																							
ALL	2010	Limousine	Powertrain	Engine Control Module										V																																																					
ALL	2010	Limousine	Powertrain	Transmission Control Module																																																																

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																													
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																																												
ALL	2010	Limousine	Body	Amplifier (Bose)																																																												
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																												
ALL	2010	Limousine	Body	Body Control Module															V	V	V	V	V	V	V																																							
ALL	2010	Limousine	Body	Climate Control Seat Module																																																												
ALL	2010	Limousine	Body	Digital Radio Receiver																																																												
ALL	2010	Limousine	Body	Driver Door Switch																																																												
ALL	2010	Limousine	Body	Driver Position Module																																																												
ALL	2010	Limousine	Body	HVAC Control Module																																																												
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2010	Limousine	Body	Passenger Door Switch																																																												
ALL	2010	Limousine	Body	Passenger Presence System																																																												
ALL	2010	Limousine	Body	Radio																																																												
ALL	2010	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2010	Limousine	Body	Theft Deterrent Module																																																												
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																								V																																				
ALL	2011	Hearse	Powertrain	Engine Control Module										V																																																		
ALL	2011	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2011	Hearse	Body	Amplifier (Bose)																																																												
ALL	2011	Hearse	Body	Body Control Module															V	V	V	V	V	V	V																																							
ALL	2011	Hearse	Body	Climate Control Seat Module																																																												
ALL	2011	Hearse	Body	Digital Radio Receiver																																																												
ALL	2011	Hearse	Body	Driver Door Switch																																																												
ALL	2011	Hearse	Body	Driver Position Module																																																												
ALL	2011	Hearse	Body	HVAC Control Module																																																												
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2011	Hearse	Body	Passenger Door Switch																																																												
ALL	2011	Hearse	Body	Passenger Presence System																																																												
ALL	2011	Hearse	Body	Radio																																																												
ALL	2011	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2011	Hearse	Body	Theft Deterrent Module																																																												
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																								V																																				
ALL	2011	Limousine	Powertrain	Engine Control Module										V																																																		
ALL	2011	Limousine	Powertrain	Transmission Control Module																																																												
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																												
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																																												
ALL	2011	Limousine	Body	Amplifier (Bose)																																																												
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																												
ALL	2011	Limousine	Body	Body Control Module															V	V	V	V	V	V	V																																							
ALL	2011	Limousine	Body	Climate Control Seat Module																																																												
ALL	2011	Limousine	Body	Digital Radio Receiver																																																												
ALL	2011	Limousine	Body	Driver Door Switch																																																												
ALL	2011	Limousine	Body	Driver Position Module																																																												
ALL	2011	Limousine	Body	HVAC Control Module																																																												
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2011	Limousine	Body	Passenger Door Switch																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
ALL	2011	Limousine	Body	Passenger Presence System																																																															
ALL	2011	Limousine	Body	Radio																																																															
ALL	2011	Limousine	Body	Rear Heated Seat Module																																																															
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																																															
ALL	2011	Limousine	Body	Theft Deterrent Module																																																															
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																								V																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																															
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																											
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2004	ALL	Chassis	ESC																																																										
C	2004	ALL	Chassis	Rear Wheel Steering																																																											
C	2004	ALL	Chassis	Tire Pressure Monitor																																																											
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2004	ALL	Chassis	VSES																																																										
C	2004	ALL	Body	Amplifier (Bose)																																																											
C	2004	ALL	Body	Body Control Module																																																											
C	2004	ALL	Body	CD Changer																																																											
C	2004	ALL	Body	Chime																																																											
C	2004	ALL	Body	Driver Door Module																																																											
C	2004	ALL	Body	Driver Seat Module																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
C	2004	ALL	Body	Instrument Panel Cluster																																																											
C	2004	ALL	Body	OnStar																																																										
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Base Radio																																																										
C	2004	ALL	Body	Uplevel Radio																																																										
C	2004	ALL	Body	Navigation Radio																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																											
C	2004	ALL	Body	Rear HVAC																																																											
C	2004	ALL	Body	Rear Seat Audio																																																											
C	2004	ALL	Body	Rear Seat Entertainment																																																											
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																																
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																											
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																											
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2005	ALL	Chassis	ESC																																																										
C	2005	ALL	Chassis	Rear Wheel Steering																																																											
C	2005	ALL	Chassis	Tire Pressure Monitor																																																											
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2005	ALL	Chassis	VSES																																																										
C	2005	ALL	Body	Amplifier (Bose)																																																											
C	2005	ALL	Body	Body Control Module																																																											
C	2005	ALL	Body	CD Changer																																																											
C	2005	ALL	Body	Chime																																																											
C	2005	ALL	Body	Disc Player and Video Display																																																											
C	2005	ALL	Body	Driver Door Module																																																											
C	2005	ALL	Body	Driver Seat Module																																																											
C	2005	ALL	Body	Generator Battery Control Module																																																											
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2005	ALL	Body	Instrument Panel Cluster																																																										
C	2005	ALL	Body	Passenger Door Module																																																										
C	2005	ALL	Body	Passenger Presence System																																																										
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio																																																										
C	2005	ALL	Body	Rear Aux. Climate Module																																																										
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																																										
C	2005	ALL	Body	Remote Function Actuation																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																														
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																									
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																										
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	ALL	Chassis	Electronic Brake Control Module																																																										
C	2007	ALL	Chassis	Electronic Suspension Control																																																										
C	2007	ALL	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2007	ALL	Body	Assist Step Controller																																																									
C	2007	ALL	Body	Body Control Module																																																									
C	2007	ALL	Body	Body Control Module (aux.)																																																									
C	2007	ALL	Body	Digital Radio Receiver																																																									
C	2007	ALL	Body	Driver Door Switch																																																									
C	2007	ALL	Body	HVAC Control Module																																																									
C	2007	ALL	Body	Inside Rear View Mirror Module																																																									
C	2007	ALL	Body	Instrument Panel Cluster																																																									
C	2007	ALL	Body	Lift Gate Module																																																									
C	2007	ALL	Body	Memory Seat Module																																																									
C	2007	ALL	Body	Park Assist Module																																																									
C	2007	ALL	Body	Passenger Door Switch																																																									
C	2007	ALL	Body	Passenger Presence System																																																									
C	2007	ALL	Body	Radio																																																									
C	2007	ALL	Body	Rear Heated Seat Module																																																									
C	2007	ALL	Body	Rear HVAC/RSA																																																									
C	2007	ALL	Body	Rollover Sensor																																																									
C	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
C	2007	ALL	Body	Theft Deterrent Module																										V	V	V	V																														
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
C	2008	ALL	Chassis	Electronic Brake Control Module																																																									
C	2008	ALL	Chassis	Electronic Suspension Control																																																									
C	2008	ALL	Chassis	Trailer Brake Control Module																																																									
C	2008	ALL	Body	Amplifier (Bose)																																																									
C	2008	ALL	Body	Assist Step Controller																																																									
C	2008	ALL	Body	Body Control Module																																																									
C	2008	ALL	Body	Body Control Module (aux.)																																																									
C	2008	ALL	Body	Digital Radio Receiver																																																									
C	2008	ALL	Body	Driver Door Switch																																																									
C	2008	ALL	Body	HVAC Control Module																																																									
C	2008	ALL	Body	Inside Rear View Mirror Module																																																									
C	2008	ALL	Body	Instrument Panel Cluster																																																									
C	2008	ALL	Body	Lift Gate Module																																																									
C	2008	ALL	Body	Memory Seat Module																																																									
C	2008	ALL	Body	Park Assist Module																																																									
C	2008	ALL	Body	Passenger Door Switch																																																									
C	2008	ALL	Body	Passenger Presence System																																																									
C	2008	ALL	Body	Radio																																																									
C	2008	ALL	Body	Rear Heated Seat Module																																																									
C	2008	ALL	Body	Rear HVAC/RSA																																																									
C	2008	ALL	Body	Rollover Sensor																																																									
C	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
C	2008	ALL	Body	Theft Deterrent Module																										V	V	V	V																													
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
C	2009	ALL	Chassis	Electronic Brake Control Module																																																									
C	2009	ALL	Chassis	Electronic Suspension Control																																																									
C	2009	ALL	Chassis	Trailer Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2009	ALL	Body	Amplifier (Bose)																																																										
C	2009	ALL	Body	Assist Step Controller																																																										
C	2009	ALL	Body	Body Control Module																																																										
C	2009	ALL	Body	Body Control Module (aux.)																																																										
C	2009	ALL	Body	Digital Radio Receiver																																																										
C	2009	ALL	Body	Driver Door Switch																																																										
C	2009	ALL	Body	HVAC Control Module																																																										
C	2009	ALL	Body	Inside Rear View Mirror Module																																																										
C	2009	ALL	Body	Instrument Panel Cluster																																																										
C	2009	ALL	Body	Left Side Object Detection Module																																																										
C	2009	ALL	Body	Lift Gate Module																																																										
C	2009	ALL	Body	Memory Seat Module																																																										
C	2009	ALL	Body	Park Assist Module																																																										
C	2009	ALL	Body	Passenger Door Switch																																																										
C	2009	ALL	Body	Passenger Presence System																																																										
C	2009	ALL	Body	Radio																																																										
C	2009	ALL	Body	Rear Heated Seat Module																																																										
C	2009	ALL	Body	Rear HVAC/RSA																																																										
C	2009	ALL	Body	Right Side Object Detection Module																																																										
C	2009	ALL	Body	Rollover Sensor																																																										
C	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2009	ALL	Body	Theft Deterrent Module																										V	V	V	V																														
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	ALL	Chassis	Electronic Brake Control Module																																																										
C	2010	ALL	Chassis	Electronic Suspension Control																																																										
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	ALL	Body	Amplifier (Bose)																																																										
C	2010	ALL	Body	Assist Step Controller																																																										
C	2010	ALL	Body	Body Control Module																																																										
C	2010	ALL	Body	Body Control Module (aux.)																																																										
C	2010	ALL	Body	Digital Radio Receiver																																																										
C	2010	ALL	Body	Driver Door Switch																																																										
C	2010	ALL	Body	HVAC Control Module																																																										
C	2010	ALL	Body	Inside Rear View Mirror Module																																																										
C	2010	ALL	Body	Instrument Panel Cluster																																																										
C	2010	ALL	Body	Left Side Object Detection Module																																																										
C	2010	ALL	Body	Lift Gate Module																																																										
C	2010	ALL	Body	Memory Seat Module																																																										
C	2010	ALL	Body	Park Assist Module																																																										
C	2010	ALL	Body	Passenger Door Switch																																																										
C	2010	ALL	Body	Passenger Presence System																																																										
C	2010	ALL	Body	Radio																																																										
C	2010	ALL	Body	Rear Heated Seat Module																																																										
C	2010	ALL	Body	Rear HVAC/RSA																																																										
C	2010	ALL	Body	Right Side Object Detection Module																																																										
C	2010	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2010	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																									
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																									
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																									
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																																									
E	2004	ALL	Chassis	Electronic Suspension Control																																																									
E	2004	ALL	Chassis	Tire Pressure Monitor																																																									
E	2004	ALL	Chassis	VES																																																									
E	2004	ALL	Body	Amplifier (Bose)																																																									
E	2004	ALL	Body	Amplifier (Delco)																																																									
E	2004	ALL	Body	Climate Control Panel																																																									
E	2004	ALL	Body	Dash Integration Module																																																									
E	2004	ALL	Body	Disc Player and Video Display																																																									
E	2004	ALL	Body	Driver Door Switch																																																									
E	2004	ALL	Body	Driver Door Module																																																									
E	2004	ALL	Body	Passenger Door Module																																																									
E	2004	ALL	Body	Left Rear Door Module																																																									
E	2004	ALL	Body	Right Rear Door Module																																																									
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																									
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																									
E	2004	ALL	Body	Instrument Panel Cluster																																																									
E	2004	ALL	Body	Memory Seat Module																																																									
E	2004	ALL	Body	OnStar																																																									
E	2004	ALL	Body	Personalization																																																									
E	2004	ALL	Body	Base Radio																																																									
E	2004	ALL	Body	Navigation Radio																V																																									
E	2004	ALL	Body	Rear Integration Module																																																									
E	2004	ALL	Body	Rear Seat Module																																																									
E	2004	ALL	Body	Remote Function Actuation																																																									
E	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
E	2004	ALL	Body	TV Antenna Module																																																									
E	2004	ALL	Body	Vehicle Theft Deterrent																																																									
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																									
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																									
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																									
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																																									
E	2005	ALL	Chassis	Electronic Suspension Control																																																									
E	2005	ALL	Chassis	Tire Pressure Monitor																																																									
E	2005	ALL	Chassis	VES																																																									
E	2005	ALL	Body	Amplifier (Bose)																																																									
E	2005	ALL	Body	Amplifier (Delco)																																																									
E	2005	ALL	Body	Climate Control Panel																																																									
E	2005	ALL	Body	Dash Integration Module																																																									
E	2005	ALL	Body	Disc Player and Video Display																																																									
E	2005	ALL	Body	Driver Door Switch																																																									
E	2005	ALL	Body	Driver Door Module																																																									
E	2005	ALL	Body	Passenger Door Module																																																									
E	2005	ALL	Body	Left Rear Door Module																																																									
E	2005	ALL	Body	Right Rear Door Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2005	ALL	Body	Instrument Panel Cluster																																																										
E	2005	ALL	Body	Memory Seat Module																																																										
E	2005	ALL	Body	Personalization																																																										
E	2005	ALL	Body	Base Radio																																																										
E	2005	ALL	Body	Navigation Radio																V																																									
E	2005	ALL	Body	Rear Integration Module																																																										
E	2005	ALL	Body	Rear Seat Module																																																										
E	2005	ALL	Body	Remote Function Actuation																																																										
E	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2005	ALL	Body	TV Antenna Module																																																										
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
E	2005	ALL	Body	Vehicle Theft Deterrent																																																										
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																										
E	2006	ALL	Chassis	Electronic Suspension Control																																																										
E	2006	ALL	Chassis	Tire Pressure Monitor																																																										
E	2006	ALL	Chassis	VES																																																										
E	2006	ALL	Body	Amplifier (Bose)																																																										
E	2006	ALL	Body	Amplifier (Delco)																																																										
E	2006	ALL	Body	Climate Control Panel																																																										
E	2006	ALL	Body	Dash Integration Module																																																										
E	2006	ALL	Body	Disc Player and Video Display																																																										
E	2006	ALL	Body	Driver Door Switch																																																										
E	2006	ALL	Body	Driver Door Module																																																										
E	2006	ALL	Body	Passenger Door Module																																																										
E	2006	ALL	Body	Left Rear Door Module																																																										
E	2006	ALL	Body	Right Rear Door Module																																																										
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2006	ALL	Body	Instrument Panel Cluster																																																										
E	2006	ALL	Body	Lift Gate Module																																																										
E	2006	ALL	Body	Memory Seat Module																																																										
E	2006	ALL	Body	Personalization																																																										
E	2006	ALL	Body	Base Radio																																																										
E	2006	ALL	Body	Navigation Radio																V																																									
E	2006	ALL	Body	Rear Integration Module																																																										
E	2006	ALL	Body	Rear Seat Module																																																										
E	2006	ALL	Body	Remote Function Actuation																																																										
E	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
E	2006	ALL	Body	Vehicle Theft Deterrent																																																										
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2007	ALL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
E	2007	ALL	Chassis	Electronic Suspension Control																																																									
E	2007	ALL	Body	Amplifier (Bose)																																																									
E	2007	ALL	Body	Body Control Module																																																									
E	2007	ALL	Body	Body Control Module (aux.)																																																									
E	2007	ALL	Body	Digital Radio Receiver																																																									
E	2007	ALL	Body	Driver Door Switch																																																									
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																									
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																									
E	2007	ALL	Body	HVAC Control Module																																																									
E	2007	ALL	Body	Instrument Panel Cluster																																																									
E	2007	ALL	Body	Lift Gate Module																																																									
E	2007	ALL	Body	Memory Seat Module																																																									
E	2007	ALL	Body	Park Assist Module																																																									
E	2007	ALL	Body	Passenger Door Switch																																																									
E	2007	ALL	Body	Passenger Presence System																																																									
E	2007	ALL	Body	Radio																																																									
E	2007	ALL	Body	Rear HVAC/RSA																																																									
E	2007	ALL	Body	Rear Seat Module																																																									
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																									
E	2007	ALL	Body	Rollover Sensor																																																									
E	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
E	2007	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
E	2007	ALL	Body	TV Antenna Module																																																									
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																									
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																									
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																									
E	2008	ALL	Chassis	Electronic Brake Control Module																																																									
E	2008	ALL	Chassis	Electronic Suspension Control																																																									
E	2008	ALL	Body	Amplifier (Bose)																																																									
E	2008	ALL	Body	Body Control Module																																																									
E	2008	ALL	Body	Body Control Module (aux.)																																																									
E	2008	ALL	Body	Digital Radio Receiver																																																									
E	2008	ALL	Body	Driver Door Switch																																																									
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																									
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																									
E	2008	ALL	Body	HVAC Control Module																																																									
E	2008	ALL	Body	Instrument Panel Cluster																																																									
E	2008	ALL	Body	Lift Gate Module																																																									
E	2008	ALL	Body	Memory Seat Module																																																									
E	2008	ALL	Body	Park Assist Module																																																									
E	2008	ALL	Body	Passenger Door Switch																																																									
E	2008	ALL	Body	Passenger Presence System																																																									
E	2008	ALL	Body	Radio																																																									
E	2008	ALL	Body	Rear HVAC/RSA																																																									
E	2008	ALL	Body	Rear Seat Module																																																									
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																									
E	2008	ALL	Body	Rollover Sensor																																																									
E	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
E	2008	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
E	2008	ALL	Body	TV Antenna Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2009	ALL	Chassis	Electronic Brake Control Module																																																										
E	2009	ALL	Chassis	Electronic Suspension Control																																																										
E	2009	ALL	Body	Amplifier (Bose)																																																										
E	2009	ALL	Body	Body Control Module																																																										
E	2009	ALL	Body	Body Control Module (aux.)																																																										
E	2009	ALL	Body	Digital Radio Receiver																																																										
E	2009	ALL	Body	Driver Door Switch																																																										
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2009	ALL	Body	HVAC Control Module																																																										
E	2009	ALL	Body	Instrument Panel Cluster																																																										
E	2009	ALL	Body	Lift Gate Module																																																										
E	2009	ALL	Body	Memory Seat Module																																																										
E	2009	ALL	Body	Park Assist Module																																																										
E	2009	ALL	Body	Passenger Door Switch																																																										
E	2009	ALL	Body	Passenger Presence System																																																										
E	2009	ALL	Body	Radio																																																										
E	2009	ALL	Body	Rear HVAC/RSA																																																										
E	2009	ALL	Body	Rear Seat Module																																																										
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
E	2009	ALL	Body	Rollover Sensor																																																										
E	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2009	ALL	Body	Theft Deterrent Module																										V	V	V	V																													
E	2009	ALL	Body	TV Antenna Module																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																															
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2004	ALL	Chassis	ESC																																																									
K	2004	ALL	Chassis	Rear Wheel Steering																																																										
K	2004	ALL	Chassis	Tire Pressure Monitor																																																										
K	2004	ALL	Chassis	VSES																																																									
K	2004	ALL	Body	Amplifier (Bose)																																																										
K	2004	ALL	Body	Body Control Module																																																										
K	2004	ALL	Body	CD Changer																																																										
K	2004	ALL	Body	Chime																																																										
K	2004	ALL	Body	Driver Door Module																																																										
K	2004	ALL	Body	Driver Seat Module																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2004	ALL	Body	Instrument Panel Cluster																																																										
K	2004	ALL	Body	OnStar																																																										
K	2004	ALL	Body	Passenger Door Module																																																										
K	2004	ALL	Body	Passenger Presence System																																																										
K	2004	ALL	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2004	ALL	Body	Uplevel Radio																																																										
K	2004	ALL	Body	Navigation Radio																																																										
K	2004	ALL	Body	Rear Aux. Climate Module																																																										
K	2004	ALL	Body	Rear HVAC																																																										
K	2004	ALL	Body	Rear Seat Audio																																																										
K	2004	ALL	Body	Rear Seat Entertainment																																																										
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																															
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	ESC																																																									
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	VSES																																																									
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Remote Function Actuation																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																															
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2006	ALL	Chassis	ESC																																																									
K	2006	ALL	Chassis	Tire Pressure Monitor																																																										
K	2006	ALL	Chassis	VSES																																																									
K	2006	ALL	Body	Amplifier (Bose)																																																										
K	2006	ALL	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2006	ALL	Body	CD Changer																																																									
K	2006	ALL	Body	Chime																																																									
K	2006	ALL	Body	Disc Player and Video Display																																																									
K	2006	ALL	Body	Driver Door Module																																																									
K	2006	ALL	Body	Driver Seat Module																																																									
K	2006	ALL	Body	Generator Battery Control Module																																																									
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																									
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2006	ALL	Body	Instrument Panel Cluster																																																									
K	2006	ALL	Body	Passenger Door Module																																																									
K	2006	ALL	Body	Passenger Presence System																																																									
K	2006	ALL	Body	Base Radio																																																									
K	2006	ALL	Body	Uplevel Radio																																																									
K	2006	ALL	Body	Navigation Radio																																																									
K	2006	ALL	Body	Rear Aux. Climate Module																																																									
K	2006	ALL	Body	Rear HVAC																																																									
K	2006	ALL	Body	Rear Seat Audio																																																									
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2007	ALL	Chassis	Electronic Brake Control Module																																																									
K	2007	ALL	Chassis	Electronic Suspension Control																																																									
K	2007	ALL	Body	Amplifier (Bose)																																																									
K	2007	ALL	Body	Assist Step Controller																																																									
K	2007	ALL	Body	Body Control Module																																																									
K	2007	ALL	Body	Body Control Module (aux.)																																																									
K	2007	ALL	Body	Digital Radio Receiver																																																									
K	2007	ALL	Body	Driver Door Switch																																																									
K	2007	ALL	Body	HVAC Control Module																																																									
K	2007	ALL	Body	Inside Rear View Mirror Module																																																									
K	2007	ALL	Body	Instrument Panel Cluster																																																									
K	2007	ALL	Body	Lift Gate Module																																																									
K	2007	ALL	Body	Memory Seat Module																																																									
K	2007	ALL	Body	Park Assist Module																																																									
K	2007	ALL	Body	Passenger Door Switch																																																									
K	2007	ALL	Body	Passenger Presence System																																																									
K	2007	ALL	Body	Radio																																																									
K	2007	ALL	Body	Rear Heated Seat Module																																																									
K	2007	ALL	Body	Rear HVAC/RSA																																																									
K	2007	ALL	Body	Rollover Sensor																																																									
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2007	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2008	ALL	Chassis	Electronic Brake Control Module																																																									
K	2008	ALL	Chassis	Electronic Suspension Control																																																									
K	2008	ALL	Chassis	Trailer Brake Control Module																																																									
K	2008	ALL	Body	Amplifier (Bose)																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2008	ALL	Body	Assist Step Controller																																																									
K	2008	ALL	Body	Body Control Module																																																									
K	2008	ALL	Body	Body Control Module (aux.)																																																									
K	2008	ALL	Body	Digital Radio Receiver																																																									
K	2008	ALL	Body	Driver Door Switch																																																									
K	2008	ALL	Body	HVAC Control Module																																																									
K	2008	ALL	Body	Inside Rear View Mirror Module																																																									
K	2008	ALL	Body	Instrument Panel Cluster																																																									
K	2008	ALL	Body	Lift Gate Module																																																									
K	2008	ALL	Body	Memory Seat Module																																																									
K	2008	ALL	Body	Park Assist Module																																																									
K	2008	ALL	Body	Passenger Door Switch																																																									
K	2008	ALL	Body	Passenger Presence System																																																									
K	2008	ALL	Body	Radio																																																									
K	2008	ALL	Body	Rear Heated Seat Module																																																									
K	2008	ALL	Body	Rear HVAC/RSA																																																									
K	2008	ALL	Body	Rollover Sensor																																																									
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2008	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
K	2009	ALL	Chassis	Electronic Brake Control Module																																																									
K	2009	ALL	Chassis	Electronic Suspension Control																																																									
K	2009	ALL	Chassis	Trailer Brake Control Module																																																									
K	2009	ALL	Body	Amplifier (Bose)																																																									
K	2009	ALL	Body	Assist Step Controller																																																									
K	2009	ALL	Body	Body Control Module																																																									
K	2009	ALL	Body	Body Control Module (aux.)																																																									
K	2009	ALL	Body	Digital Radio Receiver																																																									
K	2009	ALL	Body	Driver Door Switch																																																									
K	2009	ALL	Body	HVAC Control Module																																																									
K	2009	ALL	Body	Inside Rear View Mirror Module																																																									
K	2009	ALL	Body	Instrument Panel Cluster																																																									
K	2009	ALL	Body	Left Side Object Detection Module																																																									
K	2009	ALL	Body	Lift Gate Module																																																									
K	2009	ALL	Body	Memory Seat Module																																																									
K	2009	ALL	Body	Park Assist Module																																																									
K	2009	ALL	Body	Passenger Door Switch																																																									
K	2009	ALL	Body	Passenger Presence System																																																									
K	2009	ALL	Body	Radio																																																									
K	2009	ALL	Body	Rear Heated Seat Module																																																									
K	2009	ALL	Body	Rear HVAC/RSA																																																									
K	2009	ALL	Body	Right Side Object Detection Module																																																									
K	2009	ALL	Body	Rollover Sensor																																																									
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2009	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	ALL	Chassis	Electronic Brake Control Module																																																										
K	2010	ALL	Chassis	Electronic Suspension Control																																																										
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	ALL	Body	Amplifier (Bose)																																																										
K	2010	ALL	Body	Assist Step Controller																																																										
K	2010	ALL	Body	Body Control Module																																																										
K	2010	ALL	Body	Body Control Module (aux.)																																																										
K	2010	ALL	Body	Digital Radio Receiver																																																										
K	2010	ALL	Body	Driver Door Switch																																																										
K	2010	ALL	Body	HVAC Control Module																																																										
K	2010	ALL	Body	Inside Rear View Mirror Module																																																										
K	2010	ALL	Body	Instrument Panel Cluster																																																										
K	2010	ALL	Body	Left Side Object Detection Module																																																										
K	2010	ALL	Body	Lift Gate Module																																																										
K	2010	ALL	Body	Memory Seat Module																																																										
K	2010	ALL	Body	Park Assist Module																																																										
K	2010	ALL	Body	Passenger Door Switch																																																										
K	2010	ALL	Body	Passenger Presence System																																																										
K	2010	ALL	Body	Radio																																																										
K	2010	ALL	Body	Rear Heated Seat Module																																																										
K	2010	ALL	Body	Rear HVAC/RSA																																																										
K	2010	ALL	Body	Right Side Object Detection Module																																																										
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2010	ALL	Body	Theft Deterrent Module																										V	V	V	V																													
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																										
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																										
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																										
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2010	SRX	Chassis	Electronic Brake Control Module																																																										
N	2010	SRX	Chassis	Parking Brake Control Module																																																										
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2010	SRX	Chassis	Suspension Control Module																																																										
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2010	SRX	Body	Passenger Presence Module																																																										
N	2010	SRX	Body	Instrument Cluster																																																										
N	2010	SRX	Body	Headlamp Control Module																																																										
N	2010	SRX	Body	Trailer Interface Control Module																																																										
N	2010	SRX	Body	Radio																																																										
N	2010	SRX	Body	Rear Audio Control Module																																																										
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2010	SRX	Body	Multimedia Player Interface Module																																																										
N	2010	SRX	Body	Mobile Telephone Control Module																																																										
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2010	SRX	Body	Liftgate Control Module																																																										
N	2010	SRX	Body	Seat Memory Control Module	V																																																									
N	2010	SRX	Body	Front Seat Heating Control Module																																																										
N	2010	SRX	Body	Rear Seat Heating Control Module																																																										
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2010	SRX	Body	Parking Assist Control Module																																																										
N	2010	SRX	Body	Steering Column Lock Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2011	SRX	Chassis	Electronic Brake Control Module																																																										
N	2011	SRX	Chassis	Parking Brake Control Module																																																										
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2011	SRX	Chassis	Suspension Control Module																																																										
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2011	SRX	Body	Passenger Presence Module																																																										
N	2011	SRX	Body	Instrument Cluster																																																										
N	2011	SRX	Body	Headlamp Control Module																																																										
N	2011	SRX	Body	Trailer Interface Control Module																																																										
N	2011	SRX	Body	Radio																																																										
N	2011	SRX	Body	Rear Audio Control Module																																																										
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2011	SRX	Body	Multimedia Player Interface Module																																																										
N	2011	SRX	Body	Mobile Telephone Control Module																																																										
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2011	SRX	Body	Liftgate Control Module																																																										
N	2011	SRX	Body	Seat Memory Control Module																																																										
N	2011	SRX	Body	Front Seat Heating Control Module																																																										
N	2011	SRX	Body	Rear Seat Heating Control Module																																																										
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2011	SRX	Body	Parking Assist Control Module																																																										
N	2011	SRX	Body	Steering Column Lock Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																									
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2012	SRX	Chassis	Electronic Brake Control Module																																																									
N	2012	SRX	Chassis	Parking Brake Control Module																																																									
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2012	SRX	Chassis	Suspension Control Module																																																									
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2012	SRX	Body	Passenger Presence Module																																																									
N	2012	SRX	Body	Instrument Cluster																																																									
N	2012	SRX	Body	Headlamp Control Module																																																									
N	2012	SRX	Body	Trailer Interface Control Module																																																									
N	2012	SRX	Body	Radio																																																									
N	2012	SRX	Body	Rear Audio Control Module																																																									
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																									
N	2012	SRX	Body	Multimedia Player Interface Module																																																									
N	2012	SRX	Body	Mobile Telephone Control Module																																																									
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																																									
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																																									
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																									
N	2012	SRX	Body	Liftgate Control Module																																																									
N	2012	SRX	Body	Seat Memory Control Module																																																									
N	2012	SRX	Body	Front Seat Heating Control Module																																																									
N	2012	SRX	Body	Rear Seat Heating Control Module																																																									
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																									
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
N	2012	SRX	Body	Parking Assist Control Module																																																									
N	2012	SRX	Body	Steering Column Lock Control Module																																																									
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2013	SRX	Chassis	Electronic Brake Control Module																																																									
N	2013	SRX	Chassis	Parking Brake Control Module																																																									
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2013	SRX	Chassis	Suspension Control Module																																																									
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2013	SRX	Body	Passenger Presence Module																																																									
N	2013	SRX	Body	Instrument Cluster																																																									
N	2013	SRX	Body	Radio/HVAC Control																																																									
N	2013	SRX	Body	Active Safety Control Module																																																									
N	2013	SRX	Body	Headlamp Control Module																																																									
N	2013	SRX	Body	Trailer Interface Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
N	2013	SRX	Body	Radio																																																										
N	2013	SRX	Body	Amplifier																																																										
N	2013	SRX	Body	Media Disc Player																																																										
N	2013	SRX	Body	Human Machine Interface Control Module																																																										
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2013	SRX	Body	Liftgate Control Module																																																										
N	2013	SRX	Body	Seat Memory Control Module																																																										
N	2013	SRX	Body	Rear Seat Heating Control Module																																																										
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2013	SRX	Body	Right Side Object Detection Control Module																																																										
N	2013	SRX	Body	Left Side Object Detection Control Module																																																										
N	2013	SRX	Body	Parking Assist Control Module																																																										
N	2013	SRX	Body	Frontview Camera Module																																																										
N	2013	SRX	Body	Steering Column Lock Control Module																																																										
N	2013	SRX	Body	Long Range Radar Sensor Module																																																										
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																										
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2014	SRX	Chassis	Electronic Brake Control Module																																																										
N	2014	SRX	Chassis	Parking Brake Control Module																																																										
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2014	SRX	Chassis	Suspension Control Module																																																										
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2014	SRX	Body	Passenger Presence Module																																																										
N	2014	SRX	Body	Instrument Cluster																																																										
N	2014	SRX	Body	Radio/HVAC Control																																																										
N	2014	SRX	Body	Active Safety Control Module																																																										
N	2014	SRX	Body	Headlamp Control Module																																																										
N	2014	SRX	Body	Trailer Interface Control Module																																																										
N	2014	SRX	Body	Radio																																																										
N	2014	SRX	Body	Amplifier																																																										
N	2014	SRX	Body	Media Disc Player																																																										
N	2014	SRX	Body	Human Machine Interface Control Module																																																										
N	2014	SRX	Body	Navigation Control Module																																																										
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																										
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2014	SRX	Body	Liftgate Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2014	SRX	Body	Rear Seat Heating Control Module																																																										
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2014	SRX	Body	Right Side Object Detection Control Module																																																										
N	2014	SRX	Body	Left Side Object Detection Control Module																																																										
N	2014	SRX	Body	Parking Assist Control Module																																																										
N	2014	SRX	Body	Frontview Camera Module																																																										
N	2014	SRX	Body	Steering Column Lock Control Module																																																										
N	2014	SRX	Body	Long Range Radar Sensor Module																																																										
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																										
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2015	SRX	Chassis	Electronic Brake Control Module																																																										
N	2015	SRX	Chassis	Parking Brake Control Module																																																										
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2015	SRX	Chassis	Suspension Control Module																																																										
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2015	SRX	Body	Passenger Presence Module																																																										
N	2015	SRX	Body	Instrument Cluster																																																										
N	2015	SRX	Body	Radio/HVAC Control																																																										
N	2015	SRX	Body	Active Safety Control Module																																																										
N	2015	SRX	Body	Headlamp Control Module																																																										
N	2015	SRX	Body	Trailer Interface Control Module																																																										
N	2015	SRX	Body	Radio																																																										
N	2015	SRX	Body	Amplifier																																																										
N	2015	SRX	Body	Rear Audio Control Module																																																										
N	2015	SRX	Body	Media Disc Player																																																										
N	2015	SRX	Body	Human Machine Interface Control Module																																																										
N	2015	SRX	Body	Navigation Control Module																																																										
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																										
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2015	SRX	Body	Liftgate Control Module																																																										
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2015	SRX	Body	Rear Seat Heating Control Module																																																										
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2015	SRX	Body	Right Side Object Detection Control Module																																																										
N	2015	SRX	Body	Left Side Object Detection Control Module																																																										
N	2015	SRX	Body	Parking Assist Control Module																																																										
N	2015	SRX	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
N	2015	SRX	Body	Steering Column Lock Control Module																																																									
N	2015	SRX	Body	Long Range Radar Sensor Module																																																									
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																									
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																									
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																									
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2016	SRX	Chassis	Electronic Brake Control Module																																																									
N	2016	SRX	Chassis	Parking Brake Control Module																																																									
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2016	SRX	Chassis	Suspension Control Module																																																									
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2016	SRX	Body	Passenger Presence Module																																																									
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																									
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																																									
N	2016	SRX	Body	Radio/HVAC Control																																																									
N	2016	SRX	Body	Active Safety Control Module																																																									
N	2016	SRX	Body	Headlamp Control Module																																																									
N	2016	SRX	Body	Trailer Interface Control Module																																																									
N	2016	SRX	Body	Radio																																																									
N	2016	SRX	Body	Amplifier																																																									
N	2016	SRX	Body	Rear Audio Control Module																																																									
N	2016	SRX	Body	Media Disc Player																																																									
N	2016	SRX	Body	Human Machine Interface Control Module																																																									
N	2016	SRX	Body	Navigation Control Module																																																									
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																									
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																																									
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																									
N	2016	SRX	Body	Liftgate Control Module																																					V	V	V	V	V	V															
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																									
N	2016	SRX	Body	Rear Seat Heating Control Module																																																									
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																									
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
N	2016	SRX	Body	Right Side Object Detection Control Module																																																									
N	2016	SRX	Body	Left Side Object Detection Control Module																																																									
N	2016	SRX	Body	Parking Assist Control Module																																																									
N	2016	SRX	Body	Frontview Camera Module																																																									
N	2016	SRX	Body	Steering Column Lock Control Module																																																									
N	2016	SRX	Body	Long Range Radar Sensor Module																																																									
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																									
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																									
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																									
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
3	2011	ALL	Chassis	Electronic Brake Control Module																																																										
3	2011	ALL	Chassis	Electronic Suspension Control																																																										
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2011	ALL	Body	Amplifier (Bose)																																																										
3	2011	ALL	Body	Assist Step Controller																																																										
3	2011	ALL	Body	Body Control Module																																																										
3	2011	ALL	Body	Body Control Module (aux.)																																																										
3	2011	ALL	Body	Digital Radio Receiver																																																										
3	2011	ALL	Body	Driver Door Switch																																																										
3	2011	ALL	Body	HVAC Control Module																																																										
3	2011	ALL	Body	Inside Rear View Mirror Module																																																										
3	2011	ALL	Body	Instrument Panel Cluster																																																										
3	2011	ALL	Body	Left Side Object Detection Module																																																										
3	2011	ALL	Body	Lift Gate Module																																																										
3	2011	ALL	Body	Memory Seat Module																																																										
3	2011	ALL	Body	Park Assist Module																																																										
3	2011	ALL	Body	Passenger Door Switch																																																										
3	2011	ALL	Body	Passenger Presence System																																																										
3	2011	ALL	Body	Radio																																																										
3	2011	ALL	Body	Rear Heated Seat Module																																																										
3	2011	ALL	Body	Rear HVAC/RSA																																																										
3	2011	ALL	Body	Right Side Object Detection Module																																																										
3	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
3	2011	ALL	Body	Theft Deterrent Module																										V	V	V	V																													
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
3	2012	ALL	Chassis	Electronic Brake Control Module																																																										
3	2012	ALL	Chassis	Electronic Suspension Control																																																										
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2012	ALL	Body	Amplifier (Bose)																																																										
3	2012	ALL	Body	Assist Step Controller																																																										
3	2012	ALL	Body	Body Control Module																																																										
3	2012	ALL	Body	Body Control Module (aux.)																																																										
3	2012	ALL	Body	Driver Door Switch																																																										
3	2012	ALL	Body	HVAC Control Module																																																										
3	2012	ALL	Body	Inside Rear View Mirror Module																																																										
3	2012	ALL	Body	Instrument Panel Cluster																																																										
3	2012	ALL	Body	Left Side Object Detection Module																																																										
3	2012	ALL	Body	Lift Gate Module																																																										
3	2012	ALL	Body	Memory Seat Module																																																										
3	2012	ALL	Body	Park Assist Module																																																										
3	2012	ALL	Body	Passenger Door Switch																																																										
3	2012	ALL	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
3	2012	ALL	Body	Radio																																																									
3	2012	ALL	Body	Rear Heated Seat Module																																																									
3	2012	ALL	Body	Rear HVAC/RSA																																																									
3	2012	ALL	Body	Right Side Object Detection Module																																																									
3	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
3	2012	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
3	2013	ALL	Chassis	Electronic Brake Control Module																																																									
3	2013	ALL	Chassis	Electronic Suspension Control																																																									
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																									
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																									
3	2013	ALL	Body	Amplifier (Bose)																																																									
3	2013	ALL	Body	Assist Step Controller																																																									
3	2013	ALL	Body	Body Control Module																																																									
3	2013	ALL	Body	Body Control Module (aux.)																																																									
3	2013	ALL	Body	Driver Door Switch																																																									
3	2013	ALL	Body	HVAC Control Module																																																									
3	2013	ALL	Body	Inside Rear View Mirror Module																																																									
3	2013	ALL	Body	Instrument Panel Cluster																																																									
3	2013	ALL	Body	Left Side Object Detection Module																																																									
3	2013	ALL	Body	Lift Gate Module																																																									
3	2013	ALL	Body	Memory Seat Module																																																									
3	2013	ALL	Body	Park Assist Module																																																									
3	2013	ALL	Body	Passenger Door Switch																																																									
3	2013	ALL	Body	Passenger Presence System																																																									
3	2013	ALL	Body	Radio																																																									
3	2013	ALL	Body	Rear Heated Seat Module																																																									
3	2013	ALL	Body	Rear HVAC/RSA																																																									
3	2013	ALL	Body	Right Side Object Detection Module																																																									
3	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
3	2013	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																									
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																									
3	2014	Escalade	Chassis	Suspension Control Module																																																									
3	2014	Escalade	Body	Body Control Module																																																									
3	2014	Escalade	Body	Auxiliary Body Control Module																																																									
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
3	2014	Escalade	Body	Passenger Presence Module																																																									
3	2014	Escalade	Body	Instrument Cluster																																																									
3	2014	Escalade	Body	Radio																																																									
3	2014	Escalade	Body	Amplifier																																																									
3	2014	Escalade	Body	Rear Audio Control Module																																																									
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																									
3	2014	Escalade	Body	Personal Audio Link Control Module																																																									
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																									
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
3	2014	Escalade	Body	HVAC Control Module																																																									
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																									
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																									
3	2014	Escalade	Body	Liftgate Control Module																																																									
3	2014	Escalade	Body	Seat Memory Control Module	V	V	V																																																						
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																									
3	2014	Escalade	Body	Assist Step Control Module																																																									
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																									
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																									
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																									
3	2014	Escalade	Body	Parking Assist Control Module																																																									
3	2014	Escalade	Body	Theft Deterrent Module				V	V																																																				
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																									
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																									
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																									
3	2014	Escalade ESV	Body	Body Control Module																																																									
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																									
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
3	2014	Escalade ESV	Body	Passenger Presence Module																																																									
3	2014	Escalade ESV	Body	Instrument Cluster																																																									
3	2014	Escalade ESV	Body	Radio																																																									
3	2014	Escalade ESV	Body	Amplifier																																																									
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																									
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																									
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																									
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																									
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																									
3	2014	Escalade ESV	Body	HVAC Control Module																																																									
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																									
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																									
3	2014	Escalade ESV	Body	Liftgate Control Module																																																									
3	2014	Escalade ESV	Body	Seat Memory Control Module	V	V	V																																																						
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																									
3	2014	Escalade ESV	Body	Assist Step Control Module																																																									
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																									
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																									
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																									
3	2014	Escalade ESV	Body	Parking Assist Control Module																																																									
3	2014	Escalade ESV	Body	Theft Deterrent Module				V	V																																																				
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																									
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																								
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																								
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																									
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																									
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																									
3	2015	Escalade	Chassis	Electronic Brake Control Module																																																									
3	2015	Escalade	Chassis	Parking Brake Control Module																																																									
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																									
3	2015	Escalade	Chassis	Power Steering Control Module																																																									
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																									
3	2015	Escalade	Chassis	Suspension Control Module																																																									
3	2015	Escalade	Body	Body Control Module																																																									
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
3	2015	Escalade	Body	Passenger Presence Module																																																									
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																									
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																									
3	2015	Escalade	Body	Instrument Cluster																																																									
3	2015	Escalade	Body	Radio/HVAC Control																																																									
3	2015	Escalade	Body	Active Safety Control Module																																																									
3	2015	Escalade	Body	Video Processing Control Module																																					V																				
3	2015	Escalade	Body	Radio																																																									
3	2015	Escalade	Body	Amplifier																																																									
3	2015	Escalade	Body	Media Disc Player																																																									
3	2015	Escalade	Body	Human Machine Interface Control Module																																																									
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																									
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																									
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																									
3	2015	Escalade	Body	HVAC Control Module																																																									
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																					V	V	V	V	V	V															
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																					V	V	V	V	V	V															
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																									
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																									
3	2015	Escalade	Body	Keyless Entry Control Module																																																									
3	2015	Escalade	Body	Assist Step Control Module																																																									
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																									
3	2015	Escalade	Body	Parking Assist Control Module																																																									
3	2015	Escalade	Body	Frontview Camera Module																																																									
3	2015	Escalade	Body	Steering Column Lock Control Module																																																									
3	2015	Escalade	Body	Battery Energy Control Module																																																									
3	2015	Escalade	Body	Long Range Radar Sensor Module																																																									
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																									
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																									
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																									
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																									
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																									
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																								
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																								
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																								
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																								
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																								
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																								
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																																								
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																								
3	2015	Escalade ESV	Chassis	Suspension Control Module																																																								
3	2015	Escalade ESV	Body	Body Control Module																																																								
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
3	2015	Escalade ESV	Body	Passenger Presence Module																																																								
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																								
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																								
3	2015	Escalade ESV	Body	Instrument Cluster																																																								
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																								
3	2015	Escalade ESV	Body	Active Safety Control Module																																																								
3	2015	Escalade ESV	Body	Video Processing Control Module																																					V																				
3	2015	Escalade ESV	Body	Radio																																																								
3	2015	Escalade ESV	Body	Amplifier																																																								
3	2015	Escalade ESV	Body	Media Disc Player																																																								
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																								
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																								
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																								
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																								
3	2015	Escalade ESV	Body	HVAC Control Module																																																								
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																						V	V	V	V	V	V													
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																						V	V	V	V	V	V													
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																								
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																								
3	2015	Escalade ESV	Body	Assist Step Control Module																																																								
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																								
3	2015	Escalade ESV	Body	Parking Assist Control Module																																																								
3	2015	Escalade ESV	Body	Frontview Camera Module																																																								
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																								
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																								
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																								
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																								
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																								
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																								
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																								
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																								
3	2016	Escalade	Chassis	Electronic Brake Control Module																																																								
3	2016	Escalade	Chassis	Parking Brake Control Module																																																								
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																								
3	2016	Escalade	Chassis	Power Steering Control Module																																																								
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																								
3	2016	Escalade	Chassis	Suspension Control Module																																																								
3	2016	Escalade	Body	Body Control Module																																																								
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
3	2016	Escalade	Body	Passenger Presence Module																																																								
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																								
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																								
3	2016	Escalade	Body	Instrument Cluster																																																								
3	2016	Escalade	Body	Radio/HVAC Control																																																								
3	2016	Escalade	Body	Active Safety Control Module																																																								
3	2016	Escalade	Body	Video Processing Control Module																																				V																				
3	2016	Escalade	Body	Radio																																																								
3	2016	Escalade	Body	Amplifier																																																								
3	2016	Escalade	Body	Media Disc Player																																																								
3	2016	Escalade	Body	Human Machine Interface Control Module																																																								
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																																								
3	2016	Escalade	Body	HVAC Control Module																																																								
3	2016	Escalade	Body	Liftgate Control Module																																					V	V	V	V	V	V														
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																								
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																								
3	2016	Escalade	Body	Keyless Entry Control Module																																																								
3	2016	Escalade	Body	Assist Step Control Module																																																								
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																								
3	2016	Escalade	Body	Parking Assist Control Module																																																								
3	2016	Escalade	Body	Frontview Camera Module																																																								
3	2016	Escalade	Body	Steering Column Lock Control Module																																																								
3	2016	Escalade	Body	Long Range Radar Sensor Module																																																								
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																								
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																								
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																								
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																								
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																															V	V																								
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																															V	V																								
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																								
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																								
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																								
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																																								
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																								
3	2016	Escalade ESV	Chassis	Suspension Control Module																																																								
3	2016	Escalade ESV	Body	Body Control Module																																																								
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
3	2016	Escalade ESV	Body	Passenger Presence Module																																																								
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																								
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																								
3	2016	Escalade ESV	Body	Instrument Cluster																																																								
3	2016	Escalade ESV	Body	Radio Control																																																								
3	2016	Escalade ESV	Body	HVAC Control																																																								
3	2016	Escalade ESV	Body	Active Safety Control Module																																																								
3	2016	Escalade ESV	Body	Video Processing Control Module																																				V																				
3	2016	Escalade ESV	Body	Radio																																																								
3	2016	Escalade ESV	Body	Amplifier																																																								
3	2016	Escalade ESV	Body	Media Disc Player																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																										
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																										
3	2016	Escalade ESV	Body	HVAC Control Module																																																										
3	2016	Escalade ESV	Body	Liftgate Control Module																																					V	V	V	V	V	V															
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																										
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																										
3	2016	Escalade ESV	Body	Assist Step Control Module																																																										
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2016	Escalade ESV	Body	Frontview Camera Module																																																										
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																										
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
4	2011	ALL	Chassis	Electronic Brake Control Module																																																										
4	2011	ALL	Chassis	Electronic Suspension Control																																																										
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																										
4	2011	ALL	Body	Amplifier (Bose)																																																										
4	2011	ALL	Body	Assist Step Controller																																																										
4	2011	ALL	Body	Body Control Module																																																										
4	2011	ALL	Body	Body Control Module (aux.)																																																										
4	2011	ALL	Body	Driver Door Switch																																																										
4	2011	ALL	Body	HVAC Control Module																																																										
4	2011	ALL	Body	Inside Rear View Mirror Module																																																										
4	2011	ALL	Body	Instrument Panel Cluster																																																										
4	2011	ALL	Body	Left Side Object Detection Module																																																										
4	2011	ALL	Body	Lift Gate Module																																																										
4	2011	ALL	Body	Memory Seat Module																																																										
4	2011	ALL	Body	Park Assist Module																																																										
4	2011	ALL	Body	Passenger Door Switch																																																										
4	2011	ALL	Body	Passenger Presence System																																																										
4	2011	ALL	Body	Radio																																																										
4	2011	ALL	Body	Rear Heated Seat Module																																																										
4	2011	ALL	Body	Rear HVAC/RSA																																																										
4	2011	ALL	Body	Right Side Object Detection Module																																																										
4	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
4	2011	ALL	Body	Theft Deterrent Module																										V	V	V	V																													
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
4	2012	ALL	Chassis	Electronic Brake Control Module																																																											
4	2012	ALL	Chassis	Electronic Suspension Control																																																											
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2012	ALL	Body	Amplifier (Bose)																																																											
4	2012	ALL	Body	Assist Step Controller																																																											
4	2012	ALL	Body	Body Control Module																																																											
4	2012	ALL	Body	Body Control Module (aux.)																																																											
4	2012	ALL	Body	Driver Door Switch																																																											
4	2012	ALL	Body	HVAC Control Module																																																											
4	2012	ALL	Body	Inside Rear View Mirror Module																																																											
4	2012	ALL	Body	Instrument Panel Cluster																																																											
4	2012	ALL	Body	Left Side Object Detection Module																																																											
4	2012	ALL	Body	Lift Gate Module																																																											
4	2012	ALL	Body	Memory Seat Module																																																											
4	2012	ALL	Body	Park Assist Module																																																											
4	2012	ALL	Body	Passenger Door Switch																																																											
4	2012	ALL	Body	Passenger Presence System																																																											
4	2012	ALL	Body	Radio																																																											
4	2012	ALL	Body	Rear Heated Seat Module																																																											
4	2012	ALL	Body	Rear HVAC/RSA																																																											
4	2012	ALL	Body	Right Side Object Detection Module																																																											
4	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
4	2012	ALL	Body	Theft Deterrent Module																										V	V	V	V																														
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
4	2013	ALL	Chassis	Electronic Brake Control Module																																																											
4	2013	ALL	Chassis	Electronic Suspension Control																																																											
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2013	ALL	Body	Amplifier (Bose)																																																											
4	2013	ALL	Body	Assist Step Controller																																																											
4	2013	ALL	Body	Body Control Module																																																											
4	2013	ALL	Body	Body Control Module (aux.)																																																											
4	2013	ALL	Body	Driver Door Switch																																																											
4	2013	ALL	Body	HVAC Control Module																																																											
4	2013	ALL	Body	Inside Rear View Mirror Module																																																											
4	2013	ALL	Body	Instrument Panel Cluster																																																											
4	2013	ALL	Body	Left Side Object Detection Module																																																											
4	2013	ALL	Body	Lift Gate Module																																																											
4	2013	ALL	Body	Memory Seat Module																																																											
4	2013	ALL	Body	Park Assist Module																																																											
4	2013	ALL	Body	Passenger Door Switch																																																											
4	2013	ALL	Body	Passenger Presence System																																																											
4	2013	ALL	Body	Radio																																																											
4	2013	ALL	Body	Rear Heated Seat Module																																																											
4	2013	ALL	Body	Rear HVAC/RSA																																																											
4	2013	ALL	Body	Right Side Object Detection Module																																																											
4	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
4	2013	ALL	Body	Theft Deterrent Module																										V	V	V	V																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade	Chassis	Suspension Control Module																																																										
4	2014	Escalade	Body	Body Control Module																																																										
4	2014	Escalade	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2014	Escalade	Body	Passenger Presence Module																																																										
4	2014	Escalade	Body	Instrument Cluster																																																										
4	2014	Escalade	Body	Radio																																																										
4	2014	Escalade	Body	Amplifier																																																										
4	2014	Escalade	Body	Rear Audio Control Module																																																										
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2014	Escalade	Body	HVAC Control Module																																																										
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Liftgate Control Module																																												V															
4	2014	Escalade	Body	Seat Memory Control Module	V	V	V																																																								
4	2014	Escalade	Body	Rear Seat Heating Control Module																																																										
4	2014	Escalade	Body	Assist Step Control Module																																																										
4	2014	Escalade	Body	Right Side Object Detection Control Module																																																										
4	2014	Escalade	Body	Left Side Object Detection Control Module																																																										
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																																										
4	2014	Escalade	Body	Parking Assist Control Module																																																										
4	2014	Escalade	Body	Theft Deterrent Module				V	V																																																					
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2014	Escalade ESV	Body	Body Control Module																																																										
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2014	Escalade ESV	Body	Passenger Presence Module																																																										
4	2014	Escalade ESV	Body	Instrument Cluster																																																										
4	2014	Escalade ESV	Body	Radio																																																										
4	2014	Escalade ESV	Body	Amplifier																																																										
4	2014	Escalade ESV	Body	Rear Audio Control Module																																																										
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2014	Escalade ESV	Body	HVAC Control Module																																																										
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																										
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
4	2014	Escalade ESV	Body	Liftgate Control Module																																											V														
4	2014	Escalade ESV	Body	Seat Memory Control Module	V	V	V																																																					
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																								
4	2014	Escalade ESV	Body	Assist Step Control Module																																																							
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																							
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																							
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																							
4	2014	Escalade ESV	Body	Parking Assist Control Module																																																							
4	2014	Escalade ESV	Body	Theft Deterrent Module				V	V																																																			
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																							
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																							
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																							
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																							
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																							
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																							
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																							
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																							
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																							
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																						
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																						
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																						
4	2015	Escalade	Chassis	Electronic Brake Control Module																																																						
4	2015	Escalade	Chassis	Parking Brake Control Module																																																						
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																						
4	2015	Escalade	Chassis	Power Steering Control Module																																																						
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																						
4	2015	Escalade	Chassis	Suspension Control Module																																																						
4	2015	Escalade	Body	Body Control Module																																																						
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
4	2015	Escalade	Body	Passenger Presence Module																																																						
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																						
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																						
4	2015	Escalade	Body	Instrument Cluster																																																						
4	2015	Escalade	Body	Radio/HVAC Control																																																						
4	2015	Escalade	Body	Active Safety Control Module																																																						
4	2015	Escalade	Body	Video Processing Control Module																																					V																			
4	2015	Escalade	Body	Radio																																																						
4	2015	Escalade	Body	Amplifier																																																						
4	2015	Escalade	Body	Media Disc Player																																																						
4	2015	Escalade	Body	Human Machine Interface Control Module																																																						
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																						
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																						
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																						
4	2015	Escalade	Body	HVAC Control Module																																																						
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																						V	V	V	V	V	V													
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																						V	V	V	V	V	V													
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																						
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																						
4	2015	Escalade	Body	Keyless Entry Control Module																																																						
4	2015	Escalade	Body	Assist Step Control Module																																																						
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																						

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
4	2015	Escalade	Body	Parking Assist Control Module																																																										
4	2015	Escalade	Body	Frontview Camera Module																																																											
4	2015	Escalade	Body	Steering Column Lock Control Module																																																										
4	2015	Escalade	Body	Battery Energy Control Module																																																										
4	2015	Escalade	Body	Long Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																										
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																										
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																																										
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2015	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2015	Escalade ESV	Body	Body Control Module																																																										
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2015	Escalade ESV	Body	Passenger Presence Module																																																										
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2015	Escalade ESV	Body	Instrument Cluster																																																										
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																										
4	2015	Escalade ESV	Body	Active Safety Control Module																																																										
4	2015	Escalade ESV	Body	Video Processing Control Module																																					V																					
4	2015	Escalade ESV	Body	Radio																																																										
4	2015	Escalade ESV	Body	Amplifier																																																										
4	2015	Escalade ESV	Body	Media Disc Player																																																										
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2015	Escalade ESV	Body	HVAC Control Module																																																										
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																						V	V	V	V	V	V														
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																						V	V	V	V	V	V														
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																										
4	2015	Escalade ESV	Body	Assist Step Control Module																																																										
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
4	2015	Escalade ESV	Body	Parking Assist Control Module																																																										
4	2015	Escalade ESV	Body	Frontview Camera Module																																																										
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																								
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																								
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																								
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																								
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																								
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																							
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																							
4	2016	Escalade	Chassis	Electronic Brake Control Module																																																								
4	2016	Escalade	Chassis	Parking Brake Control Module																																																								
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																								
4	2016	Escalade	Chassis	Power Steering Control Module																																																								
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																								
4	2016	Escalade	Chassis	Suspension Control Module																																																								
4	2016	Escalade	Body	Body Control Module																																																								
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
4	2016	Escalade	Body	Passenger Presence Module																																																								
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																								
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																								
4	2016	Escalade	Body	Instrument Cluster																																																								
4	2016	Escalade	Body	Radio/HVAC Control																																																								
4	2016	Escalade	Body	Active Safety Control Module																																																								
4	2016	Escalade	Body	Video Processing Control Module																																				V																				
4	2016	Escalade	Body	Radio																																																								
4	2016	Escalade	Body	Amplifier																																																								
4	2016	Escalade	Body	Media Disc Player																																																								
4	2016	Escalade	Body	Human Machine Interface Control Module																																																								
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																																								
4	2016	Escalade	Body	HVAC Control Module																																																								
4	2016	Escalade	Body	Liftgate Control Module																																					V	V	V	V	V	V														
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																								
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																								
4	2016	Escalade	Body	Keyless Entry Control Module																																																								
4	2016	Escalade	Body	Assist Step Control Module																																																								
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																								
4	2016	Escalade	Body	Parking Assist Control Module																																																								
4	2016	Escalade	Body	Frontview Camera Module																																																								
4	2016	Escalade	Body	Steering Column Lock Control Module																																																								
4	2016	Escalade	Body	Long Range Radar Sensor Module																																																								
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																								
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																								
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																								
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																								
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																							
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																							
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																										
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																																										
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2016	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2016	Escalade ESV	Body	Body Control Module																																																										
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2016	Escalade ESV	Body	Passenger Presence Module																																																										
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2016	Escalade ESV	Body	Instrument Cluster																																																										
4	2016	Escalade ESV	Body	Radio Control																																																										
4	2016	Escalade ESV	Body	HVAC Control																																																										
4	2016	Escalade ESV	Body	Active Safety Control Module																																																										
4	2016	Escalade ESV	Body	Video Processing Control Module																																					V																					
4	2016	Escalade ESV	Body	Radio																																																										
4	2016	Escalade ESV	Body	Amplifier																																																										
4	2016	Escalade ESV	Body	Media Disc Player																																																										
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																										
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																										
4	2016	Escalade ESV	Body	HVAC Control Module																																																										
4	2016	Escalade ESV	Body	Liftgate Control Module																																						V	V	V	V	V	V														
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																										
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																										
4	2016	Escalade ESV	Body	Assist Step Control Module																																																										
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
4	2016	Escalade ESV	Body	Parking Assist Control Module																																																										
4	2016	Escalade ESV	Body	Frontview Camera Module																																																										
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																										
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module										V																																															
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module											V																																														
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module										V																																															
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module											V																																														
ALL	2004	Hearse	Chassis	DRP/ABS/TCS																																																										
ALL	2004	Hearse	Chassis	Magna Steer																																																										
ALL	2004	Hearse	Chassis	Rear Integration Module												V	V								V																																				
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																										
ALL	2004	Hearse	Body	Amplifier (Delco)												V	V																																												
ALL	2004	Hearse	Body	Dash Integration Module												V	V	V																																										
ALL	2004	Hearse	Body	Driver Door Switch																																																										
ALL	2004	Hearse	Body	Driver Door Module																																																										
ALL	2004	Hearse	Body	Passenger Door Module																																																										
ALL	2004	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2004	Hearse	Body	Instrument Panel Module															V																																										
ALL	2004	Hearse	Body	Personalization																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
ALL	2004	Hearse	Body	Radio																	V	V	V	V																																					
ALL	2004	Hearse	Body	Rear Integration Module												V	V								V																																				
ALL	2004	Hearse	Body	Remote Function Actuation																																																									
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint												V	V																																											
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																																									
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module										V																																															
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module											V																																														
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module										V																																															
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module											V																																														
ALL	2004	Limousine	Chassis	DRP/ABS/TCS																																																										
ALL	2004	Limousine	Chassis	Magna Steer																																																									
ALL	2004	Limousine	Chassis	Rear Integration Module												V	V								V																																				
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																									
ALL	2004	Limousine	Body	Amplifier (Delco)												V	V																																											
ALL	2004	Limousine	Body	Dash Integration Module												V	V	V																																										
ALL	2004	Limousine	Body	Driver Door Switch																																																									
ALL	2004	Limousine	Body	Driver Door Module																																																									
ALL	2004	Limousine	Body	Passenger Door Module																																																									
ALL	2004	Limousine	Body	Left Mid Door Module																																																									
ALL	2004	Limousine	Body	Left Rear Door Module																																																									
ALL	2004	Limousine	Body	Right Mid Door Module																																																									
ALL	2004	Limousine	Body	Right Rear Door Module																																																									
ALL	2004	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2004	Limousine	Body	Instrument Panel Module															V																																										
ALL	2004	Limousine	Body	Memory Seat Module																																																									
ALL	2004	Limousine	Body	Navigation Radio																V																																									
ALL	2004	Limousine	Body	Personalization																																																									
ALL	2004	Limousine	Body	Radio																	V	V	V	V																																					
ALL	2004	Limousine	Body	Rear Climate Control Panel																																																										
ALL	2004	Limousine	Body	Rear Integration Module												V	V								V																																				
ALL	2004	Limousine	Body	Remote Function Actuation																																																									
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint												V	V																																											
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																																									
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module										V																																															
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module											V																																														
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module										V																																															
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module											V																																														
ALL	2005	Hearse	Chassis	DRP/ABS/TCS																																																									
ALL	2005	Hearse	Chassis	Magna Steer																																																									
ALL	2005	Hearse	Chassis	Rear Integration Module												V	V								V																																				
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																									
ALL	2005	Hearse	Body	Amplifier (Delco)												V	V																																											
ALL	2005	Hearse	Body	Dash Integration Module												V	V	V																																										
ALL	2005	Hearse	Body	Driver Door Switch																																																									
ALL	2005	Hearse	Body	Driver Door Module																																																									
ALL	2005	Hearse	Body	Passenger Door Module																																																									
ALL	2005	Hearse	Body	Instrument Panel Cluster																																																									
ALL	2005	Hearse	Body	Instrument Panel Module															V																																										
ALL	2005	Hearse	Body	Personalization																																																									
ALL	2005	Hearse	Body	Radio																	V	V	V	V																																					
ALL	2005	Hearse	Body	Rear Integration Module												V	V								V																																				

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
ALL	2005	Hearse	Body	Remote Function Actuation																																																										
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																																										
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module										V																																															
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module											V																																														
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module										V																																															
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module											V																																														
ALL	2005	Limousine	Chassis	DRP/ABS/TCS																																																										
ALL	2005	Limousine	Chassis	Magna Steer																																																										
ALL	2005	Limousine	Chassis	Rear Integration Module												V	V								V																																				
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																										
ALL	2005	Limousine	Body	Amplifier (Delco)												V	V																																												
ALL	2005	Limousine	Body	Dash Integration Module												V	V	V																																											
ALL	2005	Limousine	Body	Driver Door Switch																																																										
ALL	2005	Limousine	Body	Driver Door Module																																																										
ALL	2005	Limousine	Body	Passenger Door Module																																																										
ALL	2005	Limousine	Body	Left Mid Door Module																																																										
ALL	2005	Limousine	Body	Left Rear Door Module																																																										
ALL	2005	Limousine	Body	Right Mid Door Module																																																										
ALL	2005	Limousine	Body	Right Rear Door Module																																																										
ALL	2005	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2005	Limousine	Body	Instrument Panel Module															V																																										
ALL	2005	Limousine	Body	Memory Seat Module																																																										
ALL	2005	Limousine	Body	Navigation Radio																V																																									
ALL	2005	Limousine	Body	Personalization																																																									
ALL	2005	Limousine	Body	Radio																	V	V	V	V																																				
ALL	2005	Limousine	Body	Rear Climate Control Panel																																																										
ALL	2005	Limousine	Body	Rear Integration Module												V	V								V																																				
ALL	2005	Limousine	Body	Remote Function Actuation																																																										
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint												V	V																																												
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																																										
ALL	2006	Hearse	Powertrain	Engine Control Module										V												V																																				
ALL	2006	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2006	Hearse	Body	Amplifier (Bose)																																																										
ALL	2006	Hearse	Body	Body Control Module																																																										
ALL	2006	Hearse	Body	Digital Radio Receiver																																																										
ALL	2006	Hearse	Body	Driver Door Switch																																																										
ALL	2006	Hearse	Body	Driver Position Module																																																										
ALL	2006	Hearse	Body	HVAC Control Module																																																										
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2006	Hearse	Body	Passenger Door Switch																																																										
ALL	2006	Hearse	Body	Passenger Presence System																																																										
ALL	2006	Hearse	Body	Radio																																																										
ALL	2006	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	Hearse	Body	Theft Deterrent Module																										V	V																																
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
ALL	2006	Limousine	Powertrain	Engine Control Module										V												V																																				
ALL	2006	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2006	Limousine	Body	Amplifier (Bose)																																																										
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2006	Limousine	Body	Body Control Module																																																										
ALL	2006	Limousine	Body	Digital Radio Receiver																																																										
ALL	2006	Limousine	Body	Driver Door Switch																																																										
ALL	2006	Limousine	Body	Driver Position Module																																																										
ALL	2006	Limousine	Body	HVAC Control Module																																																										
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2006	Limousine	Body	Passenger Door Switch																																																										
ALL	2006	Limousine	Body	Passenger Presence System																																																										
ALL	2006	Limousine	Body	Radio																																																										
ALL	2006	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	Limousine	Body	Theft Deterrent Module																										V	V																															
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																																										
ALL	2007	Hearse	Powertrain	Engine Control Module										V												V																																					
ALL	2007	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Hearse	Body	Amplifier (Bose)																																																										
ALL	2007	Hearse	Body	Body Control Module																																																										
ALL	2007	Hearse	Body	Digital Radio Receiver																																																										
ALL	2007	Hearse	Body	Driver Door Switch																																																										
ALL	2007	Hearse	Body	Driver Position Module																																																										
ALL	2007	Hearse	Body	HVAC Control Module																																																										
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2007	Hearse	Body	Passenger Door Switch																																																										
ALL	2007	Hearse	Body	Passenger Presence System																																																										
ALL	2007	Hearse	Body	Radio																																																										
ALL	2007	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	Hearse	Body	Theft Deterrent Module																										V	V	V	V																													
ALL	2007	Limousine	Powertrain	Engine Control Module										V												V																																					
ALL	2007	Limousine	Powertrain	Transmission Control Module																																																											
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Limousine	Body	Amplifier (Bose)																																																										
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2007	Limousine	Body	Body Control Module																																																										
ALL	2007	Limousine	Body	Digital Radio Receiver																																																										
ALL	2007	Limousine	Body	Driver Door Switch																																																										
ALL	2007	Limousine	Body	Driver Position Module																																																										
ALL	2007	Limousine	Body	HVAC Control Module																																																										
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2007	Limousine	Body	Passenger Door Switch																																																									
ALL	2007	Limousine	Body	Passenger Presence System																																																									
ALL	2007	Limousine	Body	Radio																																																									
ALL	2007	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	Limousine	Body	Theft Deterrent Module																										V	V	V	V																													
ALL	2008	Hearse	Powertrain	Engine Control Module										V												V																																					
ALL	2008	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2008	Hearse	Body	Amplifier (Bose)																																																										
ALL	2008	Hearse	Body	Body Control Module																																																										
ALL	2008	Hearse	Body	Climate Control Seat Module																																																										
ALL	2008	Hearse	Body	Digital Radio Receiver																																																										
ALL	2008	Hearse	Body	Driver Door Switch																																																										
ALL	2008	Hearse	Body	Driver Position Module																																																										
ALL	2008	Hearse	Body	HVAC Control Module																																																										
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2008	Hearse	Body	Passenger Door Switch																																																										
ALL	2008	Hearse	Body	Passenger Presence System																																																										
ALL	2008	Hearse	Body	Radio																																																										
ALL	2008	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	Hearse	Body	Theft Deterrent Module																										V	V	V	V																													
ALL	2008	Limousine	Powertrain	Engine Control Module										V												V																																					
ALL	2008	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2008	Limousine	Body	Amplifier (Bose)																																																										
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2008	Limousine	Body	Body Control Module																																																										
ALL	2008	Limousine	Body	Climate Control Seat Module																																																										
ALL	2008	Limousine	Body	Digital Radio Receiver																																																										
ALL	2008	Limousine	Body	Driver Door Switch																																																										
ALL	2008	Limousine	Body	Driver Position Module																																																										
ALL	2008	Limousine	Body	HVAC Control Module																																																										
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2008	Limousine	Body	Passenger Door Switch																																																										
ALL	2008	Limousine	Body	Passenger Presence System																																																										
ALL	2008	Limousine	Body	Radio																																																										
ALL	2008	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	Limousine	Body	Theft Deterrent Module																										V	V	V	V																													
ALL	2009	Hearse	Powertrain	Engine Control Module										V												V																																					
ALL	2009	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2009	Hearse	Body	Amplifier (Bose)																																																										
ALL	2009	Hearse	Body	Body Control Module																																																										
ALL	2009	Hearse	Body	Climate Control Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
ALL	2009	Hearse	Body	Digital Radio Receiver																																																										
ALL	2009	Hearse	Body	Driver Door Switch																																																										
ALL	2009	Hearse	Body	Driver Position Module																																																										
ALL	2009	Hearse	Body	HVAC Control Module																																																										
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2009	Hearse	Body	Passenger Door Switch																																																										
ALL	2009	Hearse	Body	Passenger Presence System																																																										
ALL	2009	Hearse	Body	Radio																																																										
ALL	2009	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	Hearse	Body	Theft Deterrent Module																										V	V	V	V																														
ALL	2009	Limousine	Powertrain	Engine Control Module										V												V																																					
ALL	2009	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2009	Limousine	Body	Amplifier (Bose)																																																										
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2009	Limousine	Body	Body Control Module																																																										
ALL	2009	Limousine	Body	Climate Control Seat Module																																																										
ALL	2009	Limousine	Body	Digital Radio Receiver																																																										
ALL	2009	Limousine	Body	Driver Door Switch																																																										
ALL	2009	Limousine	Body	Driver Position Module																																																										
ALL	2009	Limousine	Body	HVAC Control Module																																																										
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2009	Limousine	Body	Passenger Door Switch																																																										
ALL	2009	Limousine	Body	Passenger Presence System																																																										
ALL	2009	Limousine	Body	Radio																																																										
ALL	2009	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	Limousine	Body	Theft Deterrent Module																										V	V	V	V																														
ALL	2010	Hearse	Powertrain	Engine Control Module										V												V																																					
ALL	2010	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2010	Hearse	Body	Amplifier (Bose)																																																										
ALL	2010	Hearse	Body	Body Control Module																																																										
ALL	2010	Hearse	Body	Climate Control Seat Module																																																										
ALL	2010	Hearse	Body	Digital Radio Receiver																																																										
ALL	2010	Hearse	Body	Driver Door Switch																																																										
ALL	2010	Hearse	Body	Driver Position Module																																																										
ALL	2010	Hearse	Body	HVAC Control Module																																																										
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2010	Hearse	Body	Passenger Door Switch																																																										
ALL	2010	Hearse	Body	Passenger Presence System																																																										
ALL	2010	Hearse	Body	Radio																																																										
ALL	2010	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	Hearse	Body	Theft Deterrent Module																										V	V	V	V																														
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	Limousine	Powertrain	Engine Control Module										V												V																																					
ALL	2010	Limousine	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2010	Limousine	Body	Amplifier (Bose)																																																										
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2010	Limousine	Body	Body Control Module																																																										
ALL	2010	Limousine	Body	Climate Control Seat Module																																																										
ALL	2010	Limousine	Body	Digital Radio Receiver																																																										
ALL	2010	Limousine	Body	Driver Door Switch																																																										
ALL	2010	Limousine	Body	Driver Position Module																																																										
ALL	2010	Limousine	Body	HVAC Control Module																																																										
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2010	Limousine	Body	Passenger Door Switch																																																										
ALL	2010	Limousine	Body	Passenger Presence System																																																										
ALL	2010	Limousine	Body	Radio																																																										
ALL	2010	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	Limousine	Body	Theft Deterrent Module																										V	V	V	V																														
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																																										
ALL	2011	Hearse	Powertrain	Engine Control Module										V												V																																					
ALL	2011	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2011	Hearse	Body	Amplifier (Bose)																																																										
ALL	2011	Hearse	Body	Body Control Module																																																										
ALL	2011	Hearse	Body	Climate Control Seat Module																																																										
ALL	2011	Hearse	Body	Digital Radio Receiver																																																										
ALL	2011	Hearse	Body	Driver Door Switch																																																										
ALL	2011	Hearse	Body	Driver Position Module																																																										
ALL	2011	Hearse	Body	HVAC Control Module																																																										
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2011	Hearse	Body	Passenger Door Switch																																																										
ALL	2011	Hearse	Body	Passenger Presence System																																																										
ALL	2011	Hearse	Body	Radio																																																										
ALL	2011	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2011	Hearse	Body	Theft Deterrent Module																										V	V	V	V																														
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																																										
ALL	2011	Limousine	Powertrain	Engine Control Module										V												V																																					
ALL	2011	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2011	Limousine	Body	Amplifier (Bose)																																																										
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2011	Limousine	Body	Body Control Module																																																										
ALL	2011	Limousine	Body	Climate Control Seat Module																																																										
ALL	2011	Limousine	Body	Digital Radio Receiver																																																										
ALL	2011	Limousine	Body	Driver Door Switch																																																										
ALL	2011	Limousine	Body	Driver Position Module																																																										
ALL	2011	Limousine	Body	HVAC Control Module																																																										
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2011	Limousine	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
ALL	2011	Limousine	Body	Passenger Presence System																																																										
ALL	2011	Limousine	Body	Radio																																																										
ALL	2011	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2011	Limousine	Body	Theft Deterrent Module																									V	V	V	V																														
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																													
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																													
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																													
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																													
C	2004	ALL	Chassis	ESC																																																												
C	2004	ALL	Chassis	Rear Wheel Steering																																																												
C	2004	ALL	Chassis	Tire Pressure Monitor																																																												
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2004	ALL	Chassis	VSES																																																												
C	2004	ALL	Body	Amplifier (Bose)																																																												
C	2004	ALL	Body	Body Control Module																																																												
C	2004	ALL	Body	CD Changer																																																												
C	2004	ALL	Body	Chime																																																												
C	2004	ALL	Body	Driver Door Module																																																												
C	2004	ALL	Body	Driver Seat Module																																																												
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																												
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																												
C	2004	ALL	Body	Instrument Panel Cluster																																																												
C	2004	ALL	Body	OnStar																																																											
C	2004	ALL	Body	Passenger Door Module																																																											
C	2004	ALL	Body	Passenger Presence System																																																											
C	2004	ALL	Body	Base Radio																																																											
C	2004	ALL	Body	Uplevel Radio																																																											
C	2004	ALL	Body	Navigation Radio																																																											
C	2004	ALL	Body	Rear Aux. Climate Module																																																												
C	2004	ALL	Body	Rear HVAC																																																												
C	2004	ALL	Body	Rear Seat Audio																																																												
C	2004	ALL	Body	Rear Seat Entertainment																																																												
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																												
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																												
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2005	ALL	Chassis	ESC																																																											
C	2005	ALL	Chassis	Rear Wheel Steering																																																												
C	2005	ALL	Chassis	Tire Pressure Monitor																																																												
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2005	ALL	Chassis	VSES																																																												
C	2005	ALL	Body	Amplifier (Bose)																																																												
C	2005	ALL	Body	Body Control Module																																																												
C	2005	ALL	Body	CD Changer																																																												
C	2005	ALL	Body	Chime																																																												
C	2005	ALL	Body	Disc Player and Video Display																																																												
C	2005	ALL	Body	Driver Door Module																																																												
C	2005	ALL	Body	Driver Seat Module																																																												
C	2005	ALL	Body	Generator Battery Control Module																																																												
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																														
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																															
C	2005	ALL	Body	Instrument Panel Cluster																																																															
C	2005	ALL	Body	Passenger Door Module																																																															
C	2005	ALL	Body	Passenger Presence System																																																															
C	2005	ALL	Body	Base Radio																																																															
C	2005	ALL	Body	Uplevel Radio																																																															
C	2005	ALL	Body	Navigation Radio																																																															
C	2005	ALL	Body	Rear Aux. Climate Module																																																															
C	2005	ALL	Body	Rear HVAC																																																															
C	2005	ALL	Body	Rear Seat Audio																																																															
C	2005	ALL	Body	Remote Function Actuation																																																															
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																															
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																															
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																															
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																															
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																															
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																															
C	2006	ALL	Chassis	ESC																																																															
C	2006	ALL	Chassis	Tire Pressure Monitor																																																															
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																															
C	2006	ALL	Chassis	VSES																																																															
C	2006	ALL	Body	Amplifier (Bose)																																																															
C	2006	ALL	Body	Body Control Module																																																															
C	2006	ALL	Body	CD Changer																																																															
C	2006	ALL	Body	Chime																																																															
C	2006	ALL	Body	Disc Player and Video Display																																																															
C	2006	ALL	Body	Driver Door Module																																																															
C	2006	ALL	Body	Driver Seat Module																																																															
C	2006	ALL	Body	Generator Battery Control Module																																																															
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																															
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																															
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																															
C	2006	ALL	Body	Instrument Panel Cluster																																																															
C	2006	ALL	Body	Passenger Door Module																																																															
C	2006	ALL	Body	Passenger Presence System																																																															
C	2006	ALL	Body	Base Radio																																																															
C	2006	ALL	Body	Uplevel Radio																																																															
C	2006	ALL	Body	Navigation Radio																																																															
C	2006	ALL	Body	Rear Aux. Climate Module																																																															
C	2006	ALL	Body	Rear HVAC																																																															
C	2006	ALL	Body	Rear Seat Audio																																																															
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																															
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																															
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																					
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																															
C	2007	ALL	Chassis	Electronic Brake Control Module																																																															
C	2007	ALL	Chassis	Electronic Suspension Control																																																															
C	2007	ALL	Body	Amplifier (Bose)																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2007	ALL	Body	Assist Step Controller																																																												
C	2007	ALL	Body	Body Control Module																																																												
C	2007	ALL	Body	Body Control Module (aux.)																																																												
C	2007	ALL	Body	Digital Radio Receiver																																																												
C	2007	ALL	Body	Driver Door Switch																																																												
C	2007	ALL	Body	HVAC Control Module																																																												
C	2007	ALL	Body	Inside Rear View Mirror Module																																																												
C	2007	ALL	Body	Instrument Panel Cluster																																																												
C	2007	ALL	Body	Lift Gate Module																																																												
C	2007	ALL	Body	Memory Seat Module																																																												
C	2007	ALL	Body	Park Assist Module																																																												
C	2007	ALL	Body	Passenger Door Switch																																																												
C	2007	ALL	Body	Passenger Presence System																																																												
C	2007	ALL	Body	Radio																																																												
C	2007	ALL	Body	Rear Heated Seat Module																																																												
C	2007	ALL	Body	Rear HVAC/RSA																																																												
C	2007	ALL	Body	Rollover Sensor																																																												
C	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2007	ALL	Body	Theft Deterrent Module																																																												
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																				
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	ALL	Chassis	Electronic Brake Control Module																																																												
C	2008	ALL	Chassis	Electronic Suspension Control																																																												
C	2008	ALL	Chassis	Trailer Brake Control Module																																																												
C	2008	ALL	Body	Amplifier (Bose)																																																												
C	2008	ALL	Body	Assist Step Controller																																																												
C	2008	ALL	Body	Body Control Module																																																												
C	2008	ALL	Body	Body Control Module (aux.)																																																												
C	2008	ALL	Body	Digital Radio Receiver																																																												
C	2008	ALL	Body	Driver Door Switch																																																												
C	2008	ALL	Body	HVAC Control Module																																																												
C	2008	ALL	Body	Inside Rear View Mirror Module																																																												
C	2008	ALL	Body	Instrument Panel Cluster																																																												
C	2008	ALL	Body	Lift Gate Module																																																												
C	2008	ALL	Body	Memory Seat Module																																																												
C	2008	ALL	Body	Park Assist Module																																																												
C	2008	ALL	Body	Passenger Door Switch																																																												
C	2008	ALL	Body	Passenger Presence System																																																												
C	2008	ALL	Body	Radio																																																												
C	2008	ALL	Body	Rear Heated Seat Module																																																												
C	2008	ALL	Body	Rear HVAC/RSA																																																												
C	2008	ALL	Body	Rollover Sensor																																																												
C	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2008	ALL	Body	Theft Deterrent Module																																																												
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								V																				
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	ALL	Chassis	Electronic Brake Control Module																																																												
C	2009	ALL	Chassis	Electronic Suspension Control																																																												
C	2009	ALL	Chassis	Trailer Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2009	ALL	Body	Amplifier (Bose)																																																														
C	2009	ALL	Body	Assist Step Controller																																																															
C	2009	ALL	Body	Body Control Module																																																															
C	2009	ALL	Body	Body Control Module (aux.)																																																															
C	2009	ALL	Body	Digital Radio Receiver																																																															
C	2009	ALL	Body	Driver Door Switch																																																															
C	2009	ALL	Body	HVAC Control Module																																																															
C	2009	ALL	Body	Inside Rear View Mirror Module																																																															
C	2009	ALL	Body	Instrument Panel Cluster																																																															
C	2009	ALL	Body	Left Side Object Detection Module																																																															
C	2009	ALL	Body	Lift Gate Module																																																															
C	2009	ALL	Body	Memory Seat Module																																																															
C	2009	ALL	Body	Park Assist Module																																																															
C	2009	ALL	Body	Passenger Door Switch																																																															
C	2009	ALL	Body	Passenger Presence System																																																															
C	2009	ALL	Body	Radio																																																															
C	2009	ALL	Body	Rear Heated Seat Module																																																															
C	2009	ALL	Body	Rear HVAC/RSA																																																															
C	2009	ALL	Body	Right Side Object Detection Module																																																															
C	2009	ALL	Body	Rollover Sensor																																																															
C	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
C	2009	ALL	Body	Theft Deterrent Module																																																															
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																															
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																															
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																															
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
C	2010	ALL	Chassis	Electronic Brake Control Module																																																															
C	2010	ALL	Chassis	Electronic Suspension Control																																																															
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																															
C	2010	ALL	Body	Amplifier (Bose)																																																															
C	2010	ALL	Body	Assist Step Controller																																																															
C	2010	ALL	Body	Body Control Module																																																															
C	2010	ALL	Body	Body Control Module (aux.)																																																															
C	2010	ALL	Body	Digital Radio Receiver																																																															
C	2010	ALL	Body	Driver Door Switch																																																															
C	2010	ALL	Body	HVAC Control Module																																																															
C	2010	ALL	Body	Inside Rear View Mirror Module																																																															
C	2010	ALL	Body	Instrument Panel Cluster																																																															
C	2010	ALL	Body	Left Side Object Detection Module																																																															
C	2010	ALL	Body	Lift Gate Module																																																															
C	2010	ALL	Body	Memory Seat Module																																																															
C	2010	ALL	Body	Park Assist Module																																																															
C	2010	ALL	Body	Passenger Door Switch																																																															
C	2010	ALL	Body	Passenger Presence System																																																															
C	2010	ALL	Body	Radio																																																															
C	2010	ALL	Body	Rear Heated Seat Module																																																															
C	2010	ALL	Body	Rear HVAC/RSA																																																															
C	2010	ALL	Body	Right Side Object Detection Module																																																															
C	2010	ALL	Body	Supplemental Inflatable Restraint																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2010	ALL	Body	Theft Deterrent Module																																																												
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																																												
E	2004	ALL	Chassis	Electronic Suspension Control																																																												
E	2004	ALL	Chassis	Tire Pressure Monitor																																																												
E	2004	ALL	Chassis	VES																																																												
E	2004	ALL	Body	Amplifier (Bose)																																																												
E	2004	ALL	Body	Amplifier (Delco)																																																												
E	2004	ALL	Body	Climate Control Panel																																																												
E	2004	ALL	Body	Dash Integration Module																																																												
E	2004	ALL	Body	Disc Player and Video Display																																																												
E	2004	ALL	Body	Driver Door Switch																																																												
E	2004	ALL	Body	Driver Door Module																																																												
E	2004	ALL	Body	Passenger Door Module																																																												
E	2004	ALL	Body	Left Rear Door Module																																																												
E	2004	ALL	Body	Right Rear Door Module																																																												
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																												
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																												
E	2004	ALL	Body	Instrument Panel Cluster																																																												
E	2004	ALL	Body	Memory Seat Module																																																												
E	2004	ALL	Body	OnStar																																																												
E	2004	ALL	Body	Personalization																																																												
E	2004	ALL	Body	Base Radio																																																												
E	2004	ALL	Body	Navigation Radio																																																												
E	2004	ALL	Body	Rear Integration Module																																																												
E	2004	ALL	Body	Rear Seat Module																																																												
E	2004	ALL	Body	Remote Function Actuation																																																												
E	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2004	ALL	Body	TV Antenna Module																																																												
E	2004	ALL	Body	Vehicle Theft Deterrent																																																												
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																																												
E	2005	ALL	Chassis	Electronic Suspension Control																																																												
E	2005	ALL	Chassis	Tire Pressure Monitor																																																												
E	2005	ALL	Chassis	VES																																																												
E	2005	ALL	Body	Amplifier (Bose)																																																												
E	2005	ALL	Body	Amplifier (Delco)																																																												
E	2005	ALL	Body	Climate Control Panel																																																												
E	2005	ALL	Body	Dash Integration Module																																																												
E	2005	ALL	Body	Disc Player and Video Display																																																												
E	2005	ALL	Body	Driver Door Switch																																																												
E	2005	ALL	Body	Driver Door Module																																																												
E	2005	ALL	Body	Passenger Door Module																																																												
E	2005	ALL	Body	Left Rear Door Module																																																												
E	2005	ALL	Body	Right Rear Door Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																												
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																												
E	2005	ALL	Body	Instrument Panel Cluster																																																												
E	2005	ALL	Body	Memory Seat Module																																																												
E	2005	ALL	Body	Personalization																																																												
E	2005	ALL	Body	Base Radio																																																												
E	2005	ALL	Body	Navigation Radio																																																												
E	2005	ALL	Body	Rear Integration Module																																																												
E	2005	ALL	Body	Rear Seat Module																																																												
E	2005	ALL	Body	Remote Function Actuation																																																												
E	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2005	ALL	Body	TV Antenna Module																																																												
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																												
E	2005	ALL	Body	Vehicle Theft Deterrent																																																												
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																												
E	2006	ALL	Chassis	Electronic Suspension Control																																																												
E	2006	ALL	Chassis	Tire Pressure Monitor																																																												
E	2006	ALL	Chassis	VES																																																												
E	2006	ALL	Body	Amplifier (Bose)																																																												
E	2006	ALL	Body	Amplifier (Delco)																																																												
E	2006	ALL	Body	Climate Control Panel																																																												
E	2006	ALL	Body	Dash Integration Module																																																												
E	2006	ALL	Body	Disc Player and Video Display																																																												
E	2006	ALL	Body	Driver Door Switch																																																												
E	2006	ALL	Body	Driver Door Module																																																												
E	2006	ALL	Body	Passenger Door Module																																																												
E	2006	ALL	Body	Left Rear Door Module																																																												
E	2006	ALL	Body	Right Rear Door Module																																																												
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																												
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																												
E	2006	ALL	Body	Instrument Panel Cluster																																																												
E	2006	ALL	Body	Lift Gate Module																																																												
E	2006	ALL	Body	Memory Seat Module																																																												
E	2006	ALL	Body	Personalization																																																												
E	2006	ALL	Body	Base Radio																																																												
E	2006	ALL	Body	Navigation Radio																																																												
E	2006	ALL	Body	Rear Integration Module																																																												
E	2006	ALL	Body	Rear Seat Module																																																												
E	2006	ALL	Body	Remote Function Actuation																																																												
E	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
E	2006	ALL	Body	Vehicle Theft Deterrent																																																												
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2007	ALL	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
E	2007	ALL	Chassis	Electronic Suspension Control																																																															
E	2007	ALL	Body	Amplifier (Bose)																																																															
E	2007	ALL	Body	Body Control Module																																																															
E	2007	ALL	Body	Body Control Module (aux.)																																																															
E	2007	ALL	Body	Digital Radio Receiver																																																															
E	2007	ALL	Body	Driver Door Switch																																																															
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																															
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																															
E	2007	ALL	Body	HVAC Control Module																																																															
E	2007	ALL	Body	Instrument Panel Cluster																																																															
E	2007	ALL	Body	Lift Gate Module																																																															
E	2007	ALL	Body	Memory Seat Module																																																															
E	2007	ALL	Body	Park Assist Module																																																															
E	2007	ALL	Body	Passenger Door Switch																																																															
E	2007	ALL	Body	Passenger Presence System																																																															
E	2007	ALL	Body	Radio																																																															
E	2007	ALL	Body	Rear HVAC/RSA																																																															
E	2007	ALL	Body	Rear Seat Module																																																															
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																															
E	2007	ALL	Body	Rollover Sensor																																																															
E	2007	ALL	Body	Supplemental Inflatable Restraint																																																															
E	2007	ALL	Body	Theft Deterrent Module																																																															
E	2007	ALL	Body	TV Antenna Module																																																															
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																															
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																															
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																															
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																															
E	2008	ALL	Chassis	Electronic Brake Control Module																																																															
E	2008	ALL	Chassis	Electronic Suspension Control																																																															
E	2008	ALL	Body	Amplifier (Bose)																																																															
E	2008	ALL	Body	Body Control Module																																																															
E	2008	ALL	Body	Body Control Module (aux.)																																																															
E	2008	ALL	Body	Digital Radio Receiver																																																															
E	2008	ALL	Body	Driver Door Switch																																																															
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																															
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																															
E	2008	ALL	Body	HVAC Control Module																																																															
E	2008	ALL	Body	Instrument Panel Cluster																																																															
E	2008	ALL	Body	Lift Gate Module																																																															
E	2008	ALL	Body	Memory Seat Module																																																															
E	2008	ALL	Body	Park Assist Module																																																															
E	2008	ALL	Body	Passenger Door Switch																																																															
E	2008	ALL	Body	Passenger Presence System																																																															
E	2008	ALL	Body	Radio																																																															
E	2008	ALL	Body	Rear HVAC/RSA																																																															
E	2008	ALL	Body	Rear Seat Module																																																															
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																															
E	2008	ALL	Body	Rollover Sensor																																																															
E	2008	ALL	Body	Supplemental Inflatable Restraint																																																															
E	2008	ALL	Body	Theft Deterrent Module																																																															
E	2008	ALL	Body	TV Antenna Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																														
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																															
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																															
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																															
E	2009	ALL	Chassis	Electronic Brake Control Module																																																															
E	2009	ALL	Chassis	Electronic Suspension Control																																																															
E	2009	ALL	Body	Amplifier (Bose)																																																															
E	2009	ALL	Body	Body Control Module																																																															
E	2009	ALL	Body	Body Control Module (aux.)																																																															
E	2009	ALL	Body	Digital Radio Receiver																																																															
E	2009	ALL	Body	Driver Door Switch																																																															
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																															
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																															
E	2009	ALL	Body	HVAC Control Module																																																															
E	2009	ALL	Body	Instrument Panel Cluster																																																															
E	2009	ALL	Body	Lift Gate Module																																																															
E	2009	ALL	Body	Memory Seat Module																																																															
E	2009	ALL	Body	Park Assist Module																																																															
E	2009	ALL	Body	Passenger Door Switch																																																															
E	2009	ALL	Body	Passenger Presence System																																																															
E	2009	ALL	Body	Radio																																																															
E	2009	ALL	Body	Rear HVAC/RSA																																																															
E	2009	ALL	Body	Rear Seat Module																																																															
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																															
E	2009	ALL	Body	Rollover Sensor																																																															
E	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
E	2009	ALL	Body	Theft Deterrent Module																																																															
E	2009	ALL	Body	TV Antenna Module																																																															
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																															
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																															
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																															
K	2004	ALL	Chassis	ESC																																																															
K	2004	ALL	Chassis	Rear Wheel Steering																																																															
K	2004	ALL	Chassis	Tire Pressure Monitor																																																															
K	2004	ALL	Chassis	VSES																																																															
K	2004	ALL	Body	Amplifier (Bose)																																																															
K	2004	ALL	Body	Body Control Module																																																															
K	2004	ALL	Body	CD Changer																																																															
K	2004	ALL	Body	Chime																																																															
K	2004	ALL	Body	Driver Door Module																																																															
K	2004	ALL	Body	Driver Seat Module																																																															
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																															
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																															
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																															
K	2004	ALL	Body	Instrument Panel Cluster																																																															
K	2004	ALL	Body	OnStar																																																															
K	2004	ALL	Body	Passenger Door Module																																																															
K	2004	ALL	Body	Passenger Presence System																																																															
K	2004	ALL	Body	Base Radio																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2004	ALL	Body	Uplevel Radio																																																														
K	2004	ALL	Body	Navigation Radio																																																														
K	2004	ALL	Body	Rear Aux. Climate Module																																																														
K	2004	ALL	Body	Rear HVAC																																																														
K	2004	ALL	Body	Rear Seat Audio																																																														
K	2004	ALL	Body	Rear Seat Entertainment																																																														
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																														
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																														
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																														
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																														
K	2005	ALL	Chassis	ESC																																																														
K	2005	ALL	Chassis	Rear Wheel Steering																																																														
K	2005	ALL	Chassis	Tire Pressure Monitor																																																														
K	2005	ALL	Chassis	VSES																																																														
K	2005	ALL	Body	Amplifier (Bose)																																																														
K	2005	ALL	Body	Body Control Module																																																														
K	2005	ALL	Body	CD Changer																																																														
K	2005	ALL	Body	Chime																																																														
K	2005	ALL	Body	Disc Player and Video Display																																																														
K	2005	ALL	Body	Driver Door Module																																																														
K	2005	ALL	Body	Driver Seat Module																																																														
K	2005	ALL	Body	Generator Battery Control Module																																																														
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																														
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																														
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																														
K	2005	ALL	Body	Instrument Panel Cluster																																																														
K	2005	ALL	Body	Passenger Door Module																																																														
K	2005	ALL	Body	Passenger Presence System																																																														
K	2005	ALL	Body	Base Radio																																																														
K	2005	ALL	Body	Uplevel Radio																																																														
K	2005	ALL	Body	Navigation Radio																																																														
K	2005	ALL	Body	Rear Aux. Climate Module																																																														
K	2005	ALL	Body	Rear HVAC																																																														
K	2005	ALL	Body	Rear Seat Audio																																																														
K	2005	ALL	Body	Remote Function Actuation																																																														
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																														
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																														
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																														
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																														
K	2006	ALL	Chassis	ESC																																																														
K	2006	ALL	Chassis	Tire Pressure Monitor																																																														
K	2006	ALL	Chassis	VSES																																																														
K	2006	ALL	Body	Amplifier (Bose)																																																														
K	2006	ALL	Body	Body Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2006	ALL	Body	CD Changer																																																												
K	2006	ALL	Body	Chime																																																												
K	2006	ALL	Body	Disc Player and Video Display																																																												
K	2006	ALL	Body	Driver Door Module																																																												
K	2006	ALL	Body	Driver Seat Module																																																												
K	2006	ALL	Body	Generator Battery Control Module																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2006	ALL	Body	Instrument Panel Cluster																																																												
K	2006	ALL	Body	Passenger Door Module																																																												
K	2006	ALL	Body	Passenger Presence System																																																												
K	2006	ALL	Body	Base Radio																																																												
K	2006	ALL	Body	Uplevel Radio																																																												
K	2006	ALL	Body	Navigation Radio																																																												
K	2006	ALL	Body	Rear Aux. Climate Module																																																												
K	2006	ALL	Body	Rear HVAC																																																												
K	2006	ALL	Body	Rear Seat Audio																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																									V																			
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2007	ALL	Chassis	Electronic Brake Control Module																																																												
K	2007	ALL	Chassis	Electronic Suspension Control																																																												
K	2007	ALL	Body	Amplifier (Bose)																																																												
K	2007	ALL	Body	Assist Step Controller																																																												
K	2007	ALL	Body	Body Control Module																																																												
K	2007	ALL	Body	Body Control Module (aux.)																																																												
K	2007	ALL	Body	Digital Radio Receiver																																																												
K	2007	ALL	Body	Driver Door Switch																																																												
K	2007	ALL	Body	HVAC Control Module																																																												
K	2007	ALL	Body	Inside Rear View Mirror Module																																																												
K	2007	ALL	Body	Instrument Panel Cluster																																																												
K	2007	ALL	Body	Lift Gate Module																																																												
K	2007	ALL	Body	Memory Seat Module																																																												
K	2007	ALL	Body	Park Assist Module																																																												
K	2007	ALL	Body	Passenger Door Switch																																																												
K	2007	ALL	Body	Passenger Presence System																																																												
K	2007	ALL	Body	Radio																																																												
K	2007	ALL	Body	Rear Heated Seat Module																																																												
K	2007	ALL	Body	Rear HVAC/RSA																																																												
K	2007	ALL	Body	Rollover Sensor																																																												
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2007	ALL	Body	Theft Deterrent Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																									V																			
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2008	ALL	Chassis	Electronic Brake Control Module																																																												
K	2008	ALL	Chassis	Electronic Suspension Control																																																												
K	2008	ALL	Chassis	Trailer Brake Control Module																																																												
K	2008	ALL	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2008	ALL	Body	Assist Step Controller																																																												
K	2008	ALL	Body	Body Control Module																																																												
K	2008	ALL	Body	Body Control Module (aux.)																																																												
K	2008	ALL	Body	Digital Radio Receiver																																																												
K	2008	ALL	Body	Driver Door Switch																																																												
K	2008	ALL	Body	HVAC Control Module																																																												
K	2008	ALL	Body	Inside Rear View Mirror Module																																																												
K	2008	ALL	Body	Instrument Panel Cluster																																																												
K	2008	ALL	Body	Lift Gate Module																																																												
K	2008	ALL	Body	Memory Seat Module																																																												
K	2008	ALL	Body	Park Assist Module																																																												
K	2008	ALL	Body	Passenger Door Switch																																																												
K	2008	ALL	Body	Passenger Presence System																																																												
K	2008	ALL	Body	Radio																																																												
K	2008	ALL	Body	Rear Heated Seat Module																																																												
K	2008	ALL	Body	Rear HVAC/RSA																																																												
K	2008	ALL	Body	Rollover Sensor																																																												
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2008	ALL	Body	Theft Deterrent Module																																																												
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																									V																			
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	ALL	Chassis	Electronic Brake Control Module																																																												
K	2009	ALL	Chassis	Electronic Suspension Control																																																												
K	2009	ALL	Chassis	Trailer Brake Control Module																																																												
K	2009	ALL	Body	Amplifier (Bose)																																																												
K	2009	ALL	Body	Assist Step Controller																																																												
K	2009	ALL	Body	Body Control Module																																																												
K	2009	ALL	Body	Body Control Module (aux.)																																																												
K	2009	ALL	Body	Digital Radio Receiver																																																												
K	2009	ALL	Body	Driver Door Switch																																																												
K	2009	ALL	Body	HVAC Control Module																																																												
K	2009	ALL	Body	Inside Rear View Mirror Module																																																												
K	2009	ALL	Body	Instrument Panel Cluster																																																												
K	2009	ALL	Body	Left Side Object Detection Module																																																												
K	2009	ALL	Body	Lift Gate Module																																																												
K	2009	ALL	Body	Memory Seat Module																																																												
K	2009	ALL	Body	Park Assist Module																																																												
K	2009	ALL	Body	Passenger Door Switch																																																												
K	2009	ALL	Body	Passenger Presence System																																																												
K	2009	ALL	Body	Radio																																																												
K	2009	ALL	Body	Rear Heated Seat Module																																																												
K	2009	ALL	Body	Rear HVAC/RSA																																																												
K	2009	ALL	Body	Right Side Object Detection Module																																																												
K	2009	ALL	Body	Rollover Sensor																																																												
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2009	ALL	Body	Theft Deterrent Module																																																												
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2010	ALL	Chassis	Electronic Brake Control Module																																																													
K	2010	ALL	Chassis	Electronic Suspension Control																																																												
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	ALL	Body	Amplifier (Bose)																																																												
K	2010	ALL	Body	Assist Step Controller																																																												
K	2010	ALL	Body	Body Control Module																																																												
K	2010	ALL	Body	Body Control Module (aux.)																																																												
K	2010	ALL	Body	Digital Radio Receiver																																																												
K	2010	ALL	Body	Driver Door Switch																																																												
K	2010	ALL	Body	HVAC Control Module																																																												
K	2010	ALL	Body	Inside Rear View Mirror Module																																																												
K	2010	ALL	Body	Instrument Panel Cluster																																																												
K	2010	ALL	Body	Left Side Object Detection Module																																																												
K	2010	ALL	Body	Lift Gate Module																																																												
K	2010	ALL	Body	Memory Seat Module																																																												
K	2010	ALL	Body	Park Assist Module																																																												
K	2010	ALL	Body	Passenger Door Switch																																																												
K	2010	ALL	Body	Passenger Presence System																																																												
K	2010	ALL	Body	Radio																																																												
K	2010	ALL	Body	Rear Heated Seat Module																																																												
K	2010	ALL	Body	Rear HVAC/RSA																																																												
K	2010	ALL	Body	Right Side Object Detection Module																																																												
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2010	ALL	Body	Theft Deterrent Module																																																												
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																												
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																												
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																												
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																												
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2010	SRX	Chassis	Electronic Brake Control Module																																																												
N	2010	SRX	Chassis	Parking Brake Control Module																																																												
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2010	SRX	Chassis	Suspension Control Module																																																												
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2010	SRX	Body	Passenger Presence Module																																																												
N	2010	SRX	Body	Instrument Cluster																																																												
N	2010	SRX	Body	Headlamp Control Module																																																												
N	2010	SRX	Body	Trailer Interface Control Module																																																												
N	2010	SRX	Body	Radio																																																												
N	2010	SRX	Body	Rear Audio Control Module																																																												
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																												
N	2010	SRX	Body	Multimedia Player Interface Module																																																												
N	2010	SRX	Body	Mobile Telephone Control Module																																																												
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																														
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																															
N	2010	SRX	Body	Liftgate Control Module																																																															
N	2010	SRX	Body	Seat Memory Control Module																																																															
N	2010	SRX	Body	Front Seat Heating Control Module																																																															
N	2010	SRX	Body	Rear Seat Heating Control Module																																																															
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																															
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																															
N	2010	SRX	Body	Parking Assist Control Module																																																															
N	2010	SRX	Body	Steering Column Lock Control Module																																																															
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																															
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																															
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																															
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																															
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																															
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																															
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																															
N	2011	SRX	Chassis	Electronic Brake Control Module																																																															
N	2011	SRX	Chassis	Parking Brake Control Module																																																															
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																															
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																															
N	2011	SRX	Chassis	Suspension Control Module																																																															
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																															
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																															
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
N	2011	SRX	Body	Passenger Presence Module																																																															
N	2011	SRX	Body	Instrument Cluster																																																															
N	2011	SRX	Body	Headlamp Control Module																																																															
N	2011	SRX	Body	Trailer Interface Control Module																																																															
N	2011	SRX	Body	Radio																																																															
N	2011	SRX	Body	Rear Audio Control Module																																																															
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																															
N	2011	SRX	Body	Multimedia Player Interface Module																																																															
N	2011	SRX	Body	Mobile Telephone Control Module																																																															
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																															
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																															
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																															
N	2011	SRX	Body	Liftgate Control Module																																																															
N	2011	SRX	Body	Seat Memory Control Module																																																															
N	2011	SRX	Body	Front Seat Heating Control Module																																																															
N	2011	SRX	Body	Rear Seat Heating Control Module																																																															
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																															
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																															
N	2011	SRX	Body	Parking Assist Control Module																																																															
N	2011	SRX	Body	Steering Column Lock Control Module																																																															
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																															
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																															
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																															
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																														
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																														
N	2012	SRX	Chassis	Electronic Brake Control Module																																																														
N	2012	SRX	Chassis	Parking Brake Control Module																																																														
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																														
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																																														
N	2012	SRX	Chassis	Suspension Control Module																																																														
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
N	2012	SRX	Body	Passenger Presence Module																																																														
N	2012	SRX	Body	Instrument Cluster																																																														
N	2012	SRX	Body	Headlamp Control Module																																																														
N	2012	SRX	Body	Trailer Interface Control Module																																																														
N	2012	SRX	Body	Radio																																																														
N	2012	SRX	Body	Rear Audio Control Module																																																														
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																														
N	2012	SRX	Body	Multimedia Player Interface Module																																																														
N	2012	SRX	Body	Mobile Telephone Control Module																																																														
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																																														
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																																														
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																														
N	2012	SRX	Body	Liftgate Control Module																																																														
N	2012	SRX	Body	Seat Memory Control Module																																																														
N	2012	SRX	Body	Front Seat Heating Control Module																																																														
N	2012	SRX	Body	Rear Seat Heating Control Module																																																														
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																														
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																														
N	2012	SRX	Body	Parking Assist Control Module																																																														
N	2012	SRX	Body	Steering Column Lock Control Module																																																														
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																														
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																														
N	2013	SRX	Chassis	Electronic Brake Control Module																																																														
N	2013	SRX	Chassis	Parking Brake Control Module																																																														
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																														
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																																														
N	2013	SRX	Chassis	Suspension Control Module																																																														
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
N	2013	SRX	Body	Passenger Presence Module																																																														
N	2013	SRX	Body	Instrument Cluster																																																														
N	2013	SRX	Body	Radio/HVAC Control																																																														
N	2013	SRX	Body	Active Safety Control Module																																																														
N	2013	SRX	Body	Headlamp Control Module																																																														
N	2013	SRX	Body	Trailer Interface Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
N	2013	SRX	Body	Radio																																																														
N	2013	SRX	Body	Amplifier																																																														
N	2013	SRX	Body	Media Disc Player																																																														
N	2013	SRX	Body	Human Machine Interface Control Module																																																														
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																																														
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																																														
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																														
N	2013	SRX	Body	Liftgate Control Module																																																															
N	2013	SRX	Body	Seat Memory Control Module																																																															
N	2013	SRX	Body	Rear Seat Heating Control Module																																																															
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																															
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																															
N	2013	SRX	Body	Right Side Object Detection Control Module																																																															
N	2013	SRX	Body	Left Side Object Detection Control Module																																																															
N	2013	SRX	Body	Parking Assist Control Module																																																															
N	2013	SRX	Body	Frontview Camera Module																																																															
N	2013	SRX	Body	Steering Column Lock Control Module																																																															
N	2013	SRX	Body	Long Range Radar Sensor Module																																																															
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																															
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																															
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																															
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																															
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																															
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																															
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																															
N	2014	SRX	Chassis	Electronic Brake Control Module																																																															
N	2014	SRX	Chassis	Parking Brake Control Module																																																															
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																															
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																																															
N	2014	SRX	Chassis	Suspension Control Module																																																															
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																															
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																															
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
N	2014	SRX	Body	Passenger Presence Module																																																															
N	2014	SRX	Body	Instrument Cluster																																																															
N	2014	SRX	Body	Radio/HVAC Control																																																															
N	2014	SRX	Body	Active Safety Control Module																																																															
N	2014	SRX	Body	Headlamp Control Module																																																															
N	2014	SRX	Body	Trailer Interface Control Module																																																															
N	2014	SRX	Body	Radio																																																															
N	2014	SRX	Body	Amplifier																																																															
N	2014	SRX	Body	Media Disc Player																																																															
N	2014	SRX	Body	Human Machine Interface Control Module																																																															
N	2014	SRX	Body	Navigation Control Module																																																															
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																															
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																																															
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																															
N	2014	SRX	Body	Liftgate Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																														
N	2014	SRX	Body	Rear Seat Heating Control Module																																																														
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																														
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																														
N	2014	SRX	Body	Right Side Object Detection Control Module																																																														
N	2014	SRX	Body	Left Side Object Detection Control Module																																																														
N	2014	SRX	Body	Parking Assist Control Module																																																														
N	2014	SRX	Body	Frontview Camera Module																																																														
N	2014	SRX	Body	Steering Column Lock Control Module																																																														
N	2014	SRX	Body	Long Range Radar Sensor Module																																																														
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																														
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																														
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																														
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																														
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																														
N	2015	SRX	Chassis	Electronic Brake Control Module																																																														
N	2015	SRX	Chassis	Parking Brake Control Module																																																														
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																														
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																																														
N	2015	SRX	Chassis	Suspension Control Module																																																														
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
N	2015	SRX	Body	Passenger Presence Module																																																														
N	2015	SRX	Body	Instrument Cluster																																																														
N	2015	SRX	Body	Radio/HVAC Control																																																														
N	2015	SRX	Body	Active Safety Control Module																																																														
N	2015	SRX	Body	Headlamp Control Module																																																														
N	2015	SRX	Body	Trailer Interface Control Module																																																														
N	2015	SRX	Body	Radio																																																														
N	2015	SRX	Body	Amplifier																																																														
N	2015	SRX	Body	Rear Audio Control Module																																																														
N	2015	SRX	Body	Media Disc Player																																																														
N	2015	SRX	Body	Human Machine Interface Control Module																																																														
N	2015	SRX	Body	Navigation Control Module																																																														
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																														
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																																														
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																														
N	2015	SRX	Body	Liftgate Control Module																																																														
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																														
N	2015	SRX	Body	Rear Seat Heating Control Module																																																														
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																														
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																														
N	2015	SRX	Body	Right Side Object Detection Control Module																																																														
N	2015	SRX	Body	Left Side Object Detection Control Module																																																														
N	2015	SRX	Body	Parking Assist Control Module																																																														
N	2015	SRX	Body	Frontview Camera Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
N	2015	SRX	Body	Steering Column Lock Control Module																																																														
N	2015	SRX	Body	Long Range Radar Sensor Module																																																															
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																															
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																															
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																															
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																															
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																															
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																															
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																															
N	2016	SRX	Chassis	Electronic Brake Control Module																																																															
N	2016	SRX	Chassis	Parking Brake Control Module																																																															
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																															
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																																															
N	2016	SRX	Chassis	Suspension Control Module																																																															
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																															
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																															
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
N	2016	SRX	Body	Passenger Presence Module																																																															
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																															
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																																															
N	2016	SRX	Body	Radio/HVAC Control																																																															
N	2016	SRX	Body	Active Safety Control Module																																																															
N	2016	SRX	Body	Headlamp Control Module																																																															
N	2016	SRX	Body	Trailer Interface Control Module																																																															
N	2016	SRX	Body	Radio																																																															
N	2016	SRX	Body	Amplifier																																																															
N	2016	SRX	Body	Rear Audio Control Module																																																															
N	2016	SRX	Body	Media Disc Player																																																															
N	2016	SRX	Body	Human Machine Interface Control Module																																																															
N	2016	SRX	Body	Navigation Control Module																																																															
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																															
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																																															
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																															
N	2016	SRX	Body	Liftgate Control Module																																																															
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																															
N	2016	SRX	Body	Rear Seat Heating Control Module																																																															
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																															
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																															
N	2016	SRX	Body	Right Side Object Detection Control Module																																																															
N	2016	SRX	Body	Left Side Object Detection Control Module																																																															
N	2016	SRX	Body	Parking Assist Control Module																																																															
N	2016	SRX	Body	Frontview Camera Module																																																															
N	2016	SRX	Body	Steering Column Lock Control Module																																																															
N	2016	SRX	Body	Long Range Radar Sensor Module																																																															
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																															
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																															
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																															
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																															
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
3	2011	ALL	Chassis	Electronic Brake Control Module																																																															
3	2011	ALL	Chassis	Electronic Suspension Control																																																															
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																															
3	2011	ALL	Body	Amplifier (Bose)																																																															
3	2011	ALL	Body	Assist Step Controller																																																															
3	2011	ALL	Body	Body Control Module																																																															
3	2011	ALL	Body	Body Control Module (aux.)																																																															
3	2011	ALL	Body	Digital Radio Receiver																																																															
3	2011	ALL	Body	Driver Door Switch																																																															
3	2011	ALL	Body	HVAC Control Module																																																															
3	2011	ALL	Body	Inside Rear View Mirror Module																																																															
3	2011	ALL	Body	Instrument Panel Cluster																																																															
3	2011	ALL	Body	Left Side Object Detection Module																																																															
3	2011	ALL	Body	Lift Gate Module																																																															
3	2011	ALL	Body	Memory Seat Module																																																															
3	2011	ALL	Body	Park Assist Module																																																															
3	2011	ALL	Body	Passenger Door Switch																																																															
3	2011	ALL	Body	Passenger Presence System																																																															
3	2011	ALL	Body	Radio																																																															
3	2011	ALL	Body	Rear Heated Seat Module																																																															
3	2011	ALL	Body	Rear HVAC/RSA																																																															
3	2011	ALL	Body	Right Side Object Detection Module																																																															
3	2011	ALL	Body	Supplemental Inflatable Restraint																																																															
3	2011	ALL	Body	Theft Deterrent Module																																																															
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																															
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																															
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																															
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
3	2012	ALL	Chassis	Electronic Brake Control Module																																																															
3	2012	ALL	Chassis	Electronic Suspension Control																																																															
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																															
3	2012	ALL	Body	Amplifier (Bose)																																																															
3	2012	ALL	Body	Assist Step Controller																																																															
3	2012	ALL	Body	Body Control Module																																																															
3	2012	ALL	Body	Body Control Module (aux.)																																																															
3	2012	ALL	Body	Driver Door Switch																																																															
3	2012	ALL	Body	HVAC Control Module																																																															
3	2012	ALL	Body	Inside Rear View Mirror Module																																																															
3	2012	ALL	Body	Instrument Panel Cluster																																																															
3	2012	ALL	Body	Left Side Object Detection Module																																																															
3	2012	ALL	Body	Lift Gate Module																																																															
3	2012	ALL	Body	Memory Seat Module																																																															
3	2012	ALL	Body	Park Assist Module																																																															
3	2012	ALL	Body	Passenger Door Switch																																																															
3	2012	ALL	Body	Passenger Presence System																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
3	2012	ALL	Body	Radio																																																												
3	2012	ALL	Body	Rear Heated Seat Module																																																												
3	2012	ALL	Body	Rear HVAC/RSA																																																												
3	2012	ALL	Body	Right Side Object Detection Module																																																												
3	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
3	2012	ALL	Body	Theft Deterrent Module																																																												
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
3	2013	ALL	Chassis	Electronic Brake Control Module																																																												
3	2013	ALL	Chassis	Electronic Suspension Control																																																												
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																												
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																												
3	2013	ALL	Body	Amplifier (Bose)																																																												
3	2013	ALL	Body	Assist Step Controller																																																												
3	2013	ALL	Body	Body Control Module																																																												
3	2013	ALL	Body	Body Control Module (aux.)																																																												
3	2013	ALL	Body	Driver Door Switch																																																												
3	2013	ALL	Body	HVAC Control Module																																																												
3	2013	ALL	Body	Inside Rear View Mirror Module																																																												
3	2013	ALL	Body	Instrument Panel Cluster																																																												
3	2013	ALL	Body	Left Side Object Detection Module																																																												
3	2013	ALL	Body	Lift Gate Module																																																												
3	2013	ALL	Body	Memory Seat Module																																																												
3	2013	ALL	Body	Park Assist Module																																																												
3	2013	ALL	Body	Passenger Door Switch																																																												
3	2013	ALL	Body	Passenger Presence System																																																												
3	2013	ALL	Body	Radio																																																												
3	2013	ALL	Body	Rear Heated Seat Module																																																												
3	2013	ALL	Body	Rear HVAC/RSA																																																												
3	2013	ALL	Body	Right Side Object Detection Module																																																												
3	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
3	2013	ALL	Body	Theft Deterrent Module																																																												
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																												
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																												
3	2014	Escalade	Chassis	Suspension Control Module																																																												
3	2014	Escalade	Body	Body Control Module																																																												
3	2014	Escalade	Body	Auxiliary Body Control Module																																																												
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
3	2014	Escalade	Body	Passenger Presence Module																																																												
3	2014	Escalade	Body	Instrument Cluster																																																												
3	2014	Escalade	Body	Radio																																																												
3	2014	Escalade	Body	Amplifier																																																												
3	2014	Escalade	Body	Rear Audio Control Module																																																												
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																												
3	2014	Escalade	Body	Personal Audio Link Control Module																																																												
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																												
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
3	2014	Escalade	Body	HVAC Control Module																																																															
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																															
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																															
3	2014	Escalade	Body	Liftgate Control Module																																																															
3	2014	Escalade	Body	Seat Memory Control Module																																																															
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																															
3	2014	Escalade	Body	Assist Step Control Module																																																															
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																															
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																															
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																															
3	2014	Escalade	Body	Parking Assist Control Module																																																															
3	2014	Escalade	Body	Theft Deterrent Module																																																															
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																															
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																															
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																															
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																															
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																															
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																															
3	2014	Escalade ESV	Body	Body Control Module																																																															
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																															
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
3	2014	Escalade ESV	Body	Passenger Presence Module																																																															
3	2014	Escalade ESV	Body	Instrument Cluster																																																															
3	2014	Escalade ESV	Body	Radio																																																															
3	2014	Escalade ESV	Body	Amplifier																																																															
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																															
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																															
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																															
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																															
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																															
3	2014	Escalade ESV	Body	HVAC Control Module																																																															
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																															
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																															
3	2014	Escalade ESV	Body	Liftgate Control Module																																																															
3	2014	Escalade ESV	Body	Seat Memory Control Module																																																															
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																															
3	2014	Escalade ESV	Body	Assist Step Control Module																																																															
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																															
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																															
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																															
3	2014	Escalade ESV	Body	Parking Assist Control Module																																																															
3	2014	Escalade ESV	Body	Theft Deterrent Module																																																															
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																															
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																															
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																															
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																															
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																															
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																															
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																															
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																															
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																												
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																												
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																												
3	2015	Escalade	Chassis	Electronic Brake Control Module																																																												
3	2015	Escalade	Chassis	Parking Brake Control Module																																																												
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																												
3	2015	Escalade	Chassis	Power Steering Control Module																																																												
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																												
3	2015	Escalade	Chassis	Suspension Control Module																														V	V																													
3	2015	Escalade	Body	Body Control Module																																																												
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
3	2015	Escalade	Body	Passenger Presence Module																																																												
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																												
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																												
3	2015	Escalade	Body	Instrument Cluster																																																												
3	2015	Escalade	Body	Radio/HVAC Control																																																												
3	2015	Escalade	Body	Active Safety Control Module																																																												
3	2015	Escalade	Body	Video Processing Control Module																																																												
3	2015	Escalade	Body	Radio																																																												
3	2015	Escalade	Body	Amplifier																																																												
3	2015	Escalade	Body	Media Disc Player																																																												
3	2015	Escalade	Body	Human Machine Interface Control Module																																																												
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																												
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																												
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																												
3	2015	Escalade	Body	HVAC Control Module																																																												
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																											
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																											
3	2015	Escalade	Body	Keyless Entry Control Module																																																											
3	2015	Escalade	Body	Assist Step Control Module																																																											
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																											
3	2015	Escalade	Body	Parking Assist Control Module																																																											
3	2015	Escalade	Body	Frontview Camera Module																																																											
3	2015	Escalade	Body	Steering Column Lock Control Module																																																											
3	2015	Escalade	Body	Battery Energy Control Module				V	V	V	V																																																				
3	2015	Escalade	Body	Long Range Radar Sensor Module																																																											
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																											
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																											
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																											
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																											
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																											
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																											
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																													
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																												
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																												
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																																												
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																												
3	2015	Escalade ESV	Chassis	Suspension Control Module																														V	V																												
3	2015	Escalade ESV	Body	Body Control Module																																																												
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
3	2015	Escalade ESV	Body	Passenger Presence Module																																																												
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																												
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																												
3	2015	Escalade ESV	Body	Instrument Cluster																																																												
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																												
3	2015	Escalade ESV	Body	Active Safety Control Module																																																												
3	2015	Escalade ESV	Body	Video Processing Control Module																																																												
3	2015	Escalade ESV	Body	Radio																																																												
3	2015	Escalade ESV	Body	Amplifier																																																												
3	2015	Escalade ESV	Body	Media Disc Player																																																												
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																												
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																												
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																												
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																												
3	2015	Escalade ESV	Body	HVAC Control Module																																																												
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																												
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																												
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																												
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																												
3	2015	Escalade ESV	Body	Assist Step Control Module																																																												
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																												
3	2015	Escalade ESV	Body	Parking Assist Control Module																																																												
3	2015	Escalade ESV	Body	Frontview Camera Module																																																												
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																												
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																												
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																												
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																												
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																												
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																												
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
3	2016	Escalade	Chassis	Electronic Brake Control Module																																																												
3	2016	Escalade	Chassis	Parking Brake Control Module																																																												
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																												
3	2016	Escalade	Chassis	Power Steering Control Module																																																												
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																												
3	2016	Escalade	Chassis	Suspension Control Module																														V	V																												
3	2016	Escalade	Body	Body Control Module																																																												
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
3	2016	Escalade	Body	Passenger Presence Module																																																													
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																													
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																													
3	2016	Escalade	Body	Instrument Cluster																																																													
3	2016	Escalade	Body	Radio/HVAC Control																																																													
3	2016	Escalade	Body	Active Safety Control Module																																																													
3	2016	Escalade	Body	Video Processing Control Module																																																													
3	2016	Escalade	Body	Radio																																																													
3	2016	Escalade	Body	Amplifier																																																													
3	2016	Escalade	Body	Media Disc Player																																																													
3	2016	Escalade	Body	Human Machine Interface Control Module																																																													
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																																													
3	2016	Escalade	Body	HVAC Control Module																																																													
3	2016	Escalade	Body	Liftgate Control Module																																																													
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																													
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																													
3	2016	Escalade	Body	Keyless Entry Control Module																																																													
3	2016	Escalade	Body	Assist Step Control Module																																																													
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																													
3	2016	Escalade	Body	Parking Assist Control Module																																																													
3	2016	Escalade	Body	Frontview Camera Module																																																													
3	2016	Escalade	Body	Steering Column Lock Control Module																																																													
3	2016	Escalade	Body	Long Range Radar Sensor Module																																																													
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																													
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																													
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																													
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																													
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																													
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																													
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																													
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																													
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																													
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																																													
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																													
3	2016	Escalade ESV	Chassis	Suspension Control Module																														V	V																														
3	2016	Escalade ESV	Body	Body Control Module																																																													
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
3	2016	Escalade ESV	Body	Passenger Presence Module																																																													
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																													
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																													
3	2016	Escalade ESV	Body	Instrument Cluster																																																													
3	2016	Escalade ESV	Body	Radio Control																																																													
3	2016	Escalade ESV	Body	HVAC Control																																																													
3	2016	Escalade ESV	Body	Active Safety Control Module																																																													
3	2016	Escalade ESV	Body	Video Processing Control Module																																																													
3	2016	Escalade ESV	Body	Radio																																																													
3	2016	Escalade ESV	Body	Amplifier																																																													
3	2016	Escalade ESV	Body	Media Disc Player																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																												
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																												
3	2016	Escalade ESV	Body	HVAC Control Module																																																												
3	2016	Escalade ESV	Body	Liftgate Control Module																																																												
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																												
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																												
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																												
3	2016	Escalade ESV	Body	Assist Step Control Module																																																												
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																												
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																												
3	2016	Escalade ESV	Body	Frontview Camera Module																																																												
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																												
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																												
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																												
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																												
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																												
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																												
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
4	2011	ALL	Chassis	Electronic Brake Control Module																																																												
4	2011	ALL	Chassis	Electronic Suspension Control																																																												
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																												
4	2011	ALL	Body	Amplifier (Bose)																																																												
4	2011	ALL	Body	Assist Step Controller																																																												
4	2011	ALL	Body	Body Control Module																																																												
4	2011	ALL	Body	Body Control Module (aux.)																																																												
4	2011	ALL	Body	Driver Door Switch																																																												
4	2011	ALL	Body	HVAC Control Module																																																												
4	2011	ALL	Body	Inside Rear View Mirror Module																																																												
4	2011	ALL	Body	Instrument Panel Cluster																																																												
4	2011	ALL	Body	Left Side Object Detection Module																																																												
4	2011	ALL	Body	Lift Gate Module																																																												
4	2011	ALL	Body	Memory Seat Module																																																												
4	2011	ALL	Body	Park Assist Module																																																												
4	2011	ALL	Body	Passenger Door Switch																																																												
4	2011	ALL	Body	Passenger Presence System																																																												
4	2011	ALL	Body	Radio																																																											
4	2011	ALL	Body	Rear Heated Seat Module																																																												
4	2011	ALL	Body	Rear HVAC/RSA																																																												
4	2011	ALL	Body	Right Side Object Detection Module																																																												
4	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
4	2011	ALL	Body	Theft Deterrent Module																																																												
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
4	2012	ALL	Chassis	Electronic Brake Control Module																																																															
4	2012	ALL	Chassis	Electronic Suspension Control																																																															
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																															
4	2012	ALL	Body	Amplifier (Bose)																																																															
4	2012	ALL	Body	Assist Step Controller																																																															
4	2012	ALL	Body	Body Control Module																																																															
4	2012	ALL	Body	Body Control Module (aux.)																																																															
4	2012	ALL	Body	Driver Door Switch																																																															
4	2012	ALL	Body	HVAC Control Module																																																															
4	2012	ALL	Body	Inside Rear View Mirror Module																																																															
4	2012	ALL	Body	Instrument Panel Cluster																																																															
4	2012	ALL	Body	Left Side Object Detection Module																																																															
4	2012	ALL	Body	Lift Gate Module																																																															
4	2012	ALL	Body	Memory Seat Module																																																															
4	2012	ALL	Body	Park Assist Module																																																															
4	2012	ALL	Body	Passenger Door Switch																																																															
4	2012	ALL	Body	Passenger Presence System																																																															
4	2012	ALL	Body	Radio																																																															
4	2012	ALL	Body	Rear Heated Seat Module																																																															
4	2012	ALL	Body	Rear HVAC/RSA																																																															
4	2012	ALL	Body	Right Side Object Detection Module																																																															
4	2012	ALL	Body	Supplemental Inflatable Restraint																																																															
4	2012	ALL	Body	Theft Deterrent Module																																																															
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																															
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																															
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																															
4	2013	ALL	Chassis	Electronic Brake Control Module																																																															
4	2013	ALL	Chassis	Electronic Suspension Control																																																															
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																															
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																															
4	2013	ALL	Body	Amplifier (Bose)																																																															
4	2013	ALL	Body	Assist Step Controller																																																															
4	2013	ALL	Body	Body Control Module																																																															
4	2013	ALL	Body	Body Control Module (aux.)																																																															
4	2013	ALL	Body	Driver Door Switch																																																															
4	2013	ALL	Body	HVAC Control Module																																																															
4	2013	ALL	Body	Inside Rear View Mirror Module																																																															
4	2013	ALL	Body	Instrument Panel Cluster																																																															
4	2013	ALL	Body	Left Side Object Detection Module																																																															
4	2013	ALL	Body	Lift Gate Module																																																															
4	2013	ALL	Body	Memory Seat Module																																																															
4	2013	ALL	Body	Park Assist Module																																																															
4	2013	ALL	Body	Passenger Door Switch																																																															
4	2013	ALL	Body	Passenger Presence System																																																															
4	2013	ALL	Body	Radio																																																															
4	2013	ALL	Body	Rear Heated Seat Module																																																															
4	2013	ALL	Body	Rear HVAC/RSA																																																															
4	2013	ALL	Body	Right Side Object Detection Module																																																															
4	2013	ALL	Body	Supplemental Inflatable Restraint																																																															
4	2013	ALL	Body	Theft Deterrent Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																												
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
4	2014	Escalade	Chassis	Electronic Brake Control Module																																																												
4	2014	Escalade	Chassis	Suspension Control Module																																																												
4	2014	Escalade	Body	Body Control Module																																																												
4	2014	Escalade	Body	Auxiliary Body Control Module																																																												
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
4	2014	Escalade	Body	Passenger Presence Module																																																												
4	2014	Escalade	Body	Instrument Cluster																																																												
4	2014	Escalade	Body	Radio																																																												
4	2014	Escalade	Body	Amplifier																																																												
4	2014	Escalade	Body	Rear Audio Control Module																																																												
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																																												
4	2014	Escalade	Body	Personal Audio Link Control Module																																																												
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																												
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																												
4	2014	Escalade	Body	HVAC Control Module																																																												
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																												
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																												
4	2014	Escalade	Body	Liftgate Control Module																																																												
4	2014	Escalade	Body	Seat Memory Control Module																																																												
4	2014	Escalade	Body	Rear Seat Heating Control Module																																																												
4	2014	Escalade	Body	Assist Step Control Module																																																												
4	2014	Escalade	Body	Right Side Object Detection Control Module																																																												
4	2014	Escalade	Body	Left Side Object Detection Control Module																																																												
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																																												
4	2014	Escalade	Body	Parking Assist Control Module																																																												
4	2014	Escalade	Body	Theft Deterrent Module																																																												
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																												
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																												
4	2014	Escalade ESV	Chassis	Suspension Control Module																																																												
4	2014	Escalade ESV	Body	Body Control Module																																																												
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																												
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
4	2014	Escalade ESV	Body	Passenger Presence Module																																																												
4	2014	Escalade ESV	Body	Instrument Cluster																																																												
4	2014	Escalade ESV	Body	Radio																																																												
4	2014	Escalade ESV	Body	Amplifier																																																												
4	2014	Escalade ESV	Body	Rear Audio Control Module																																																												
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																												
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																												
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																												
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																												
4	2014	Escalade ESV	Body	HVAC Control Module																																																												
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																												
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
4	2014	Escalade ESV	Body	Liftgate Control Module																																																														
4	2014	Escalade ESV	Body	Seat Memory Control Module																																																														
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																														
4	2014	Escalade ESV	Body	Assist Step Control Module																																																														
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																														
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																														
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																														
4	2014	Escalade ESV	Body	Parking Assist Control Module																																																														
4	2014	Escalade ESV	Body	Theft Deterrent Module																																																														
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																														
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																														
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																														
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																														
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																														
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																														
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																														
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																														
4	2015	Escalade	Chassis	Electronic Brake Control Module																																																														
4	2015	Escalade	Chassis	Parking Brake Control Module																																																														
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																														
4	2015	Escalade	Chassis	Power Steering Control Module																																																														
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																														
4	2015	Escalade	Chassis	Suspension Control Module																													V	V																															
4	2015	Escalade	Body	Body Control Module																																																														
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
4	2015	Escalade	Body	Passenger Presence Module																																																														
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																														
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																														
4	2015	Escalade	Body	Instrument Cluster																																																														
4	2015	Escalade	Body	Radio/HVAC Control																																																														
4	2015	Escalade	Body	Active Safety Control Module																																																														
4	2015	Escalade	Body	Video Processing Control Module																																																														
4	2015	Escalade	Body	Radio																																																														
4	2015	Escalade	Body	Amplifier																																																														
4	2015	Escalade	Body	Media Disc Player																																																														
4	2015	Escalade	Body	Human Machine Interface Control Module																																																														
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																														
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																														
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																														
4	2015	Escalade	Body	HVAC Control Module																																																														
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																														
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																														
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																														
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																														
4	2015	Escalade	Body	Keyless Entry Control Module																																																														
4	2015	Escalade	Body	Assist Step Control Module																																																														
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
4	2015	Escalade	Body	Parking Assist Control Module																																																												
4	2015	Escalade	Body	Frontview Camera Module																																																												
4	2015	Escalade	Body	Steering Column Lock Control Module																																																												
4	2015	Escalade	Body	Battery Energy Control Module				V	V	V	V																																																					
4	2015	Escalade	Body	Long Range Radar Sensor Module																																																												
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																												
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																												
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																												
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																												
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																												
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																												
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																												
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																												
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																												
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																																												
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																												
4	2015	Escalade ESV	Chassis	Suspension Control Module																														V	V																													
4	2015	Escalade ESV	Body	Body Control Module																																																												
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
4	2015	Escalade ESV	Body	Passenger Presence Module																																																												
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																												
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																												
4	2015	Escalade ESV	Body	Instrument Cluster																																																												
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																												
4	2015	Escalade ESV	Body	Active Safety Control Module																																																												
4	2015	Escalade ESV	Body	Video Processing Control Module																																																												
4	2015	Escalade ESV	Body	Radio																																																												
4	2015	Escalade ESV	Body	Amplifier																																																												
4	2015	Escalade ESV	Body	Media Disc Player																																																												
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																												
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																												
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																												
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																												
4	2015	Escalade ESV	Body	HVAC Control Module																																																												
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																											
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																											
4	2015	Escalade ESV	Body	Assist Step Control Module																																																											
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
4	2015	Escalade ESV	Body	Parking Assist Control Module																																																											
4	2015	Escalade ESV	Body	Frontview Camera Module																																																											
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																															
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																															
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																															
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																															
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																															
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																															
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																															
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																															
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																															
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																															
4	2016	Escalade	Chassis	Electronic Brake Control Module																																																															
4	2016	Escalade	Chassis	Parking Brake Control Module																																																															
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																															
4	2016	Escalade	Chassis	Power Steering Control Module																																																															
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																															
4	2016	Escalade	Chassis	Suspension Control Module																														V	V																																
4	2016	Escalade	Body	Body Control Module																																																															
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
4	2016	Escalade	Body	Passenger Presence Module																																																															
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																															
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																															
4	2016	Escalade	Body	Instrument Cluster																																																															
4	2016	Escalade	Body	Radio/HVAC Control																																																															
4	2016	Escalade	Body	Active Safety Control Module																																																															
4	2016	Escalade	Body	Video Processing Control Module																																																															
4	2016	Escalade	Body	Radio																																																															
4	2016	Escalade	Body	Amplifier																																																															
4	2016	Escalade	Body	Media Disc Player																																																															
4	2016	Escalade	Body	Human Machine Interface Control Module																																																															
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																																															
4	2016	Escalade	Body	HVAC Control Module																																																															
4	2016	Escalade	Body	Liftgate Control Module																																																															
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																															
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																															
4	2016	Escalade	Body	Keyless Entry Control Module																																																															
4	2016	Escalade	Body	Assist Step Control Module																																																															
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																															
4	2016	Escalade	Body	Parking Assist Control Module																																																															
4	2016	Escalade	Body	Frontview Camera Module																																																															
4	2016	Escalade	Body	Steering Column Lock Control Module																																																															
4	2016	Escalade	Body	Long Range Radar Sensor Module																																																															
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																															
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																															
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																															
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																															
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																															
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																															
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																															
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																															
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																															
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																												
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																												
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																																												
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																												
4	2016	Escalade ESV	Chassis	Suspension Control Module																														V	V																													
4	2016	Escalade ESV	Body	Body Control Module																																																												
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
4	2016	Escalade ESV	Body	Passenger Presence Module																																																												
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																												
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																												
4	2016	Escalade ESV	Body	Instrument Cluster																																																												
4	2016	Escalade ESV	Body	Radio Control																																																												
4	2016	Escalade ESV	Body	HVAC Control																																																												
4	2016	Escalade ESV	Body	Active Safety Control Module																																																												
4	2016	Escalade ESV	Body	Video Processing Control Module																																																												
4	2016	Escalade ESV	Body	Radio																																																												
4	2016	Escalade ESV	Body	Amplifier																																																												
4	2016	Escalade ESV	Body	Media Disc Player																																																												
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																												
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																												
4	2016	Escalade ESV	Body	HVAC Control Module																																																												
4	2016	Escalade ESV	Body	Liftgate Control Module																																																												
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																												
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																												
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																												
4	2016	Escalade ESV	Body	Assist Step Control Module																																																												
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																												
4	2016	Escalade ESV	Body	Parking Assist Control Module																																																												
4	2016	Escalade ESV	Body	Frontview Camera Module																																																												
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																												
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																												
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																												
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																												
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																												
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																												
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																												
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																												
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																												
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																												
ALL	2004	Hearse	Chassis	DRP/ABS/TCS																																																												
ALL	2004	Hearse	Chassis	Magna Steer																																																												
ALL	2004	Hearse	Chassis	Rear Integration Module																																																												
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																												
ALL	2004	Hearse	Body	Amplifier (Delco)																																																												
ALL	2004	Hearse	Body	Dash Integration Module																																																												
ALL	2004	Hearse	Body	Driver Door Switch																																																												
ALL	2004	Hearse	Body	Driver Door Module																																																												
ALL	2004	Hearse	Body	Passenger Door Module																																																												
ALL	2004	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2004	Hearse	Body	Instrument Panel Module																																																												
ALL	2004	Hearse	Body	Personalization																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
ALL	2004	Hearse	Body	Radio																																																														
ALL	2004	Hearse	Body	Rear Integration Module																																																														
ALL	2004	Hearse	Body	Remote Function Actuation																																																														
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																																																														
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																																														
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																														
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																														
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																														
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																														
ALL	2004	Limousine	Chassis	DRP/ABS/TCS																																																															
ALL	2004	Limousine	Chassis	Magna Steer																																																															
ALL	2004	Limousine	Chassis	Rear Integration Module																																																															
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																															
ALL	2004	Limousine	Body	Amplifier (Delco)																																																															
ALL	2004	Limousine	Body	Dash Integration Module																																																															
ALL	2004	Limousine	Body	Driver Door Switch																																																															
ALL	2004	Limousine	Body	Driver Door Module																																																															
ALL	2004	Limousine	Body	Passenger Door Module																																																															
ALL	2004	Limousine	Body	Left Mid Door Module																																																															
ALL	2004	Limousine	Body	Left Rear Door Module																																																															
ALL	2004	Limousine	Body	Right Mid Door Module																																																															
ALL	2004	Limousine	Body	Right Rear Door Module																																																															
ALL	2004	Limousine	Body	Instrument Panel Cluster																																																															
ALL	2004	Limousine	Body	Instrument Panel Module																																																															
ALL	2004	Limousine	Body	Memory Seat Module																																																															
ALL	2004	Limousine	Body	Navigation Radio																																																															
ALL	2004	Limousine	Body	Personalization																																																															
ALL	2004	Limousine	Body	Radio																																																															
ALL	2004	Limousine	Body	Rear Climate Control Panel																																																															
ALL	2004	Limousine	Body	Rear Integration Module																																																															
ALL	2004	Limousine	Body	Remote Function Actuation																																																															
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																																																															
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																																															
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																															
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																															
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																														
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																															
ALL	2005	Hearse	Chassis	DRP/ABS/TCS																																																															
ALL	2005	Hearse	Chassis	Magna Steer																																																															
ALL	2005	Hearse	Chassis	Rear Integration Module																																																															
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																															
ALL	2005	Hearse	Body	Amplifier (Delco)																																																															
ALL	2005	Hearse	Body	Dash Integration Module																																																															
ALL	2005	Hearse	Body	Driver Door Switch																																																															
ALL	2005	Hearse	Body	Driver Door Module																																																															
ALL	2005	Hearse	Body	Passenger Door Module																																																															
ALL	2005	Hearse	Body	Instrument Panel Cluster																																																															
ALL	2005	Hearse	Body	Instrument Panel Module																																																															
ALL	2005	Hearse	Body	Personalization																																																															
ALL	2005	Hearse	Body	Radio																																																															
ALL	2005	Hearse	Body	Rear Integration Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
ALL	2005	Hearse	Body	Remote Function Actuation																																																														
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																																														
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																																														
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																														
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																														
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																														
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																														
ALL	2005	Limousine	Chassis	DRP/ABS/TCS																																																														
ALL	2005	Limousine	Chassis	Magna Steer																																																														
ALL	2005	Limousine	Chassis	Rear Integration Module																																																														
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																														
ALL	2005	Limousine	Body	Amplifier (Delco)																																																														
ALL	2005	Limousine	Body	Dash Integration Module																																																														
ALL	2005	Limousine	Body	Driver Door Switch																																																														
ALL	2005	Limousine	Body	Driver Door Module																																																														
ALL	2005	Limousine	Body	Passenger Door Module																																																														
ALL	2005	Limousine	Body	Left Mid Door Module																																																														
ALL	2005	Limousine	Body	Left Rear Door Module																																																														
ALL	2005	Limousine	Body	Right Mid Door Module																																																														
ALL	2005	Limousine	Body	Right Rear Door Module																																																														
ALL	2005	Limousine	Body	Instrument Panel Cluster																																																														
ALL	2005	Limousine	Body	Instrument Panel Module																																																														
ALL	2005	Limousine	Body	Memory Seat Module																																																														
ALL	2005	Limousine	Body	Navigation Radio																																																														
ALL	2005	Limousine	Body	Personalization																																																														
ALL	2005	Limousine	Body	Radio																																																														
ALL	2005	Limousine	Body	Rear Climate Control Panel																																																														
ALL	2005	Limousine	Body	Rear Integration Module																																																														
ALL	2005	Limousine	Body	Remote Function Actuation																																																														
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint																																																														
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																																														
ALL	2006	Hearse	Powertrain	Engine Control Module																																																														
ALL	2006	Hearse	Powertrain	Transmission Control Module																																																														
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																																														
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																														
ALL	2006	Hearse	Body	Amplifier (Bose)																																																														
ALL	2006	Hearse	Body	Body Control Module																																																														
ALL	2006	Hearse	Body	Digital Radio Receiver																																																														
ALL	2006	Hearse	Body	Driver Door Switch																																																														
ALL	2006	Hearse	Body	Driver Position Module																																																														
ALL	2006	Hearse	Body	HVAC Control Module																																																														
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																														
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																														
ALL	2006	Hearse	Body	Passenger Door Switch																																																														
ALL	2006	Hearse	Body	Passenger Presence System																																																														
ALL	2006	Hearse	Body	Radio																																																														
ALL	2006	Hearse	Body	Rear Heated Seat Module																																																														
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																														
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																																														
ALL	2006	Hearse	Body	Theft Deterrent Module																																																														
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
ALL	2006	Limousine	Powertrain	Engine Control Module																																																														
ALL	2006	Limousine	Powertrain	Transmission Control Module																																																														
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																																														
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																														
ALL	2006	Limousine	Body	Amplifier (Bose)																																																													
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																													
ALL	2006	Limousine	Body	Body Control Module																																																													
ALL	2006	Limousine	Body	Digital Radio Receiver																																																													
ALL	2006	Limousine	Body	Driver Door Switch																																																													
ALL	2006	Limousine	Body	Driver Position Module																																																													
ALL	2006	Limousine	Body	HVAC Control Module																																																													
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																													
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																													
ALL	2006	Limousine	Body	Passenger Door Switch																																																													
ALL	2006	Limousine	Body	Passenger Presence System																																																													
ALL	2006	Limousine	Body	Radio																																																													
ALL	2006	Limousine	Body	Rear Heated Seat Module																																																													
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																													
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																																													
ALL	2006	Limousine	Body	Theft Deterrent Module																																																													
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																																													
ALL	2007	Hearse	Powertrain	Engine Control Module																																																													
ALL	2007	Hearse	Powertrain	Transmission Control Module																																																													
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																													
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																																													
ALL	2007	Hearse	Body	Amplifier (Bose)																																																													
ALL	2007	Hearse	Body	Body Control Module																																																													
ALL	2007	Hearse	Body	Digital Radio Receiver																																																													
ALL	2007	Hearse	Body	Driver Door Switch																																																													
ALL	2007	Hearse	Body	Driver Position Module																																																													
ALL	2007	Hearse	Body	HVAC Control Module																																																													
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																													
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																													
ALL	2007	Hearse	Body	Passenger Door Switch																																																													
ALL	2007	Hearse	Body	Passenger Presence System																																																													
ALL	2007	Hearse	Body	Radio																																																													
ALL	2007	Hearse	Body	Rear Heated Seat Module																																																													
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																																													
ALL	2007	Hearse	Body	Theft Deterrent Module																																																													
ALL	2007	Limousine	Powertrain	Engine Control Module																																																													
ALL	2007	Limousine	Powertrain	Transmission Control Module																																																													
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																													
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																																													
ALL	2007	Limousine	Body	Amplifier (Bose)																																																													
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																																													
ALL	2007	Limousine	Body	Body Control Module																																																													
ALL	2007	Limousine	Body	Digital Radio Receiver																																																													
ALL	2007	Limousine	Body	Driver Door Switch																																																													
ALL	2007	Limousine	Body	Driver Position Module																																																													
ALL	2007	Limousine	Body	HVAC Control Module																																																													
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																														
ALL	2007	Limousine	Body	Passenger Door Switch																																																														
ALL	2007	Limousine	Body	Passenger Presence System																																																														
ALL	2007	Limousine	Body	Radio																																																														
ALL	2007	Limousine	Body	Rear Heated Seat Module																																																														
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																																														
ALL	2007	Limousine	Body	Theft Deterrent Module																																																														
ALL	2008	Hearse	Powertrain	Engine Control Module																																																														
ALL	2008	Hearse	Powertrain	Transmission Control Module																																																														
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																														
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																																														
ALL	2008	Hearse	Body	Amplifier (Bose)																																																														
ALL	2008	Hearse	Body	Body Control Module																																																														
ALL	2008	Hearse	Body	Climate Control Seat Module																																																														
ALL	2008	Hearse	Body	Digital Radio Receiver																																																														
ALL	2008	Hearse	Body	Driver Door Switch																																																														
ALL	2008	Hearse	Body	Driver Position Module																																																														
ALL	2008	Hearse	Body	HVAC Control Module																																																														
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																														
ALL	2008	Hearse	Body	Passenger Door Switch																																																														
ALL	2008	Hearse	Body	Passenger Presence System																																																														
ALL	2008	Hearse	Body	Radio																																																														
ALL	2008	Hearse	Body	Rear Heated Seat Module																																																														
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																																														
ALL	2008	Hearse	Body	Theft Deterrent Module																																																														
ALL	2008	Limousine	Powertrain	Engine Control Module																																																														
ALL	2008	Limousine	Powertrain	Transmission Control Module																																																														
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																														
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																																														
ALL	2008	Limousine	Body	Amplifier (Bose)																																																														
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																														
ALL	2008	Limousine	Body	Body Control Module																																																														
ALL	2008	Limousine	Body	Climate Control Seat Module																																																														
ALL	2008	Limousine	Body	Digital Radio Receiver																																																														
ALL	2008	Limousine	Body	Driver Door Switch																																																														
ALL	2008	Limousine	Body	Driver Position Module																																																														
ALL	2008	Limousine	Body	HVAC Control Module																																																														
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																														
ALL	2008	Limousine	Body	Passenger Door Switch																																																														
ALL	2008	Limousine	Body	Passenger Presence System																																																														
ALL	2008	Limousine	Body	Radio																																																														
ALL	2008	Limousine	Body	Rear Heated Seat Module																																																														
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																																														
ALL	2008	Limousine	Body	Theft Deterrent Module																																																														
ALL	2009	Hearse	Powertrain	Engine Control Module																																																														
ALL	2009	Hearse	Powertrain	Transmission Control Module																																																														
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																														
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																																														
ALL	2009	Hearse	Body	Amplifier (Bose)																																																														
ALL	2009	Hearse	Body	Body Control Module																																																														
ALL	2009	Hearse	Body	Climate Control Seat Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
ALL	2009	Hearse	Body	Digital Radio Receiver																																																															
ALL	2009	Hearse	Body	Driver Door Switch																																																															
ALL	2009	Hearse	Body	Driver Position Module																																																															
ALL	2009	Hearse	Body	HVAC Control Module																																																															
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																															
ALL	2009	Hearse	Body	Passenger Door Switch																																																															
ALL	2009	Hearse	Body	Passenger Presence System																																																															
ALL	2009	Hearse	Body	Radio																																																															
ALL	2009	Hearse	Body	Rear Heated Seat Module																																																															
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																																															
ALL	2009	Hearse	Body	Theft Deterrent Module																																																															
ALL	2009	Limousine	Powertrain	Engine Control Module																																																															
ALL	2009	Limousine	Powertrain	Transmission Control Module																																																															
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																															
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																																															
ALL	2009	Limousine	Body	Amplifier (Bose)																																																															
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																															
ALL	2009	Limousine	Body	Body Control Module																																																															
ALL	2009	Limousine	Body	Climate Control Seat Module																																																															
ALL	2009	Limousine	Body	Digital Radio Receiver																																																															
ALL	2009	Limousine	Body	Driver Door Switch																																																															
ALL	2009	Limousine	Body	Driver Position Module																																																															
ALL	2009	Limousine	Body	HVAC Control Module																																																															
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																															
ALL	2009	Limousine	Body	Passenger Door Switch																																																															
ALL	2009	Limousine	Body	Passenger Presence System																																																															
ALL	2009	Limousine	Body	Radio																																																															
ALL	2009	Limousine	Body	Rear Heated Seat Module																																																															
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																																															
ALL	2009	Limousine	Body	Theft Deterrent Module																																																															
ALL	2010	Hearse	Powertrain	Engine Control Module																																																															
ALL	2010	Hearse	Powertrain	Transmission Control Module																																																															
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																															
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																																															
ALL	2010	Hearse	Body	Amplifier (Bose)																																																															
ALL	2010	Hearse	Body	Body Control Module																																																															
ALL	2010	Hearse	Body	Climate Control Seat Module																																																															
ALL	2010	Hearse	Body	Digital Radio Receiver																																																															
ALL	2010	Hearse	Body	Driver Door Switch																																																															
ALL	2010	Hearse	Body	Driver Position Module																																																															
ALL	2010	Hearse	Body	HVAC Control Module																																																															
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																															
ALL	2010	Hearse	Body	Passenger Door Switch																																																															
ALL	2010	Hearse	Body	Passenger Presence System																																																															
ALL	2010	Hearse	Body	Radio																																																															
ALL	2010	Hearse	Body	Rear Heated Seat Module																																																															
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																																															
ALL	2010	Hearse	Body	Theft Deterrent Module																																																															
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																																															
ALL	2010	Limousine	Powertrain	Engine Control Module																																																															
ALL	2010	Limousine	Powertrain	Transmission Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																														
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																																														
ALL	2010	Limousine	Body	Amplifier (Bose)																																																														
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																														
ALL	2010	Limousine	Body	Body Control Module																																																														
ALL	2010	Limousine	Body	Climate Control Seat Module																																																														
ALL	2010	Limousine	Body	Digital Radio Receiver																																																														
ALL	2010	Limousine	Body	Driver Door Switch																																																														
ALL	2010	Limousine	Body	Driver Position Module																																																														
ALL	2010	Limousine	Body	HVAC Control Module																																																														
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																														
ALL	2010	Limousine	Body	Passenger Door Switch																																																														
ALL	2010	Limousine	Body	Passenger Presence System																																																														
ALL	2010	Limousine	Body	Radio																																																														
ALL	2010	Limousine	Body	Rear Heated Seat Module																																																														
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																																														
ALL	2010	Limousine	Body	Theft Deterrent Module																																																														
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																																														
ALL	2011	Hearse	Powertrain	Engine Control Module																																																														
ALL	2011	Hearse	Powertrain	Transmission Control Module																																																														
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																														
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																																														
ALL	2011	Hearse	Body	Amplifier (Bose)																																																														
ALL	2011	Hearse	Body	Body Control Module																																																														
ALL	2011	Hearse	Body	Climate Control Seat Module																																																														
ALL	2011	Hearse	Body	Digital Radio Receiver																																																														
ALL	2011	Hearse	Body	Driver Door Switch																																																														
ALL	2011	Hearse	Body	Driver Position Module																																																														
ALL	2011	Hearse	Body	HVAC Control Module																																																														
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																														
ALL	2011	Hearse	Body	Passenger Door Switch																																																														
ALL	2011	Hearse	Body	Passenger Presence System																																																														
ALL	2011	Hearse	Body	Radio																																																														
ALL	2011	Hearse	Body	Rear Heated Seat Module																																																														
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																																														
ALL	2011	Hearse	Body	Theft Deterrent Module																																																														
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																																														
ALL	2011	Limousine	Powertrain	Engine Control Module																																																														
ALL	2011	Limousine	Powertrain	Transmission Control Module																																																														
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																														
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																																														
ALL	2011	Limousine	Body	Amplifier (Bose)																																																														
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																														
ALL	2011	Limousine	Body	Body Control Module																																																														
ALL	2011	Limousine	Body	Climate Control Seat Module																																																														
ALL	2011	Limousine	Body	Digital Radio Receiver																																																														
ALL	2011	Limousine	Body	Driver Door Switch																																																														
ALL	2011	Limousine	Body	Driver Position Module																																																														
ALL	2011	Limousine	Body	HVAC Control Module																																																														
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																														
ALL	2011	Limousine	Body	Passenger Door Switch																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
ALL	2011	Limousine	Body	Passenger Presence System																																																																
ALL	2011	Limousine	Body	Radio																																																																
ALL	2011	Limousine	Body	Rear Heated Seat Module																																																																
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																																																
ALL	2011	Limousine	Body	Theft Deterrent Module																																																																
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																																																

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	ESC																																																										
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																										
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Instrument Panel Cluster																																																										
C	2004	ALL	Body	OnStar																																																										
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Base Radio																																																										
C	2004	ALL	Body	Uplevel Radio																																																										
C	2004	ALL	Body	Navigation Radio																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																										
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																										
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	ESC																																																										
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2005	ALL	Chassis	VSES																																																										
C	2005	ALL	Body	Amplifier (Bose)																																																										
C	2005	ALL	Body	Body Control Module																																																										
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																																										
C	2005	ALL	Body	Driver Seat Module																																																										
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2005	ALL	Body	Instrument Panel Cluster																																																										
C	2005	ALL	Body	Passenger Door Module																																																										
C	2005	ALL	Body	Passenger Presence System																																																										
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio																																																										
C	2005	ALL	Body	Rear Aux. Climate Module																																																										
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																																										
C	2005	ALL	Body	Remote Function Actuation																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	ESC																																																										
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																										
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																										
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	ALL	Chassis	Electronic Brake Control Module																																																										
C	2007	ALL	Chassis	Electronic Suspension Control																																																										
C	2007	ALL	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2007	ALL	Body	Assist Step Controller																																																										
C	2007	ALL	Body	Body Control Module																																																										
C	2007	ALL	Body	Body Control Module (aux.)																																																										
C	2007	ALL	Body	Digital Radio Receiver																																																										
C	2007	ALL	Body	Driver Door Switch																																																										
C	2007	ALL	Body	HVAC Control Module																																																										
C	2007	ALL	Body	Inside Rear View Mirror Module																																																										
C	2007	ALL	Body	Instrument Panel Cluster																																																										
C	2007	ALL	Body	Lift Gate Module																																																										
C	2007	ALL	Body	Memory Seat Module																																																										
C	2007	ALL	Body	Park Assist Module																																																										
C	2007	ALL	Body	Passenger Door Switch																																																										
C	2007	ALL	Body	Passenger Presence System																																																										
C	2007	ALL	Body	Radio																																																										
C	2007	ALL	Body	Rear Heated Seat Module																																																										
C	2007	ALL	Body	Rear HVAC/RSA																																																										
C	2007	ALL	Body	Rollover Sensor																																																										
C	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2007	ALL	Body	Theft Deterrent Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	ALL	Chassis	Electronic Brake Control Module																																																										
C	2008	ALL	Chassis	Electronic Suspension Control																																																										
C	2008	ALL	Chassis	Trailer Brake Control Module																																																										
C	2008	ALL	Body	Amplifier (Bose)																																																										
C	2008	ALL	Body	Assist Step Controller																																																										
C	2008	ALL	Body	Body Control Module																																																										
C	2008	ALL	Body	Body Control Module (aux.)																																																										
C	2008	ALL	Body	Digital Radio Receiver																																																										
C	2008	ALL	Body	Driver Door Switch																																																										
C	2008	ALL	Body	HVAC Control Module																																																										
C	2008	ALL	Body	Inside Rear View Mirror Module																																																										
C	2008	ALL	Body	Instrument Panel Cluster																																																										
C	2008	ALL	Body	Lift Gate Module																																																										
C	2008	ALL	Body	Memory Seat Module																																																										
C	2008	ALL	Body	Park Assist Module																																																										
C	2008	ALL	Body	Passenger Door Switch																																																										
C	2008	ALL	Body	Passenger Presence System																																																										
C	2008	ALL	Body	Radio																																																										
C	2008	ALL	Body	Rear Heated Seat Module																																																										
C	2008	ALL	Body	Rear HVAC/RSA																																																										
C	2008	ALL	Body	Rollover Sensor																																																										
C	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2008	ALL	Body	Theft Deterrent Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	ALL	Chassis	Electronic Brake Control Module																																																										
C	2009	ALL	Chassis	Electronic Suspension Control																																																										
C	2009	ALL	Chassis	Trailer Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2009	ALL	Body	Amplifier (Bose)																																																										
C	2009	ALL	Body	Assist Step Controller																																																										
C	2009	ALL	Body	Body Control Module																																																										
C	2009	ALL	Body	Body Control Module (aux.)																																																										
C	2009	ALL	Body	Digital Radio Receiver																																																										
C	2009	ALL	Body	Driver Door Switch																																																										
C	2009	ALL	Body	HVAC Control Module																																																										
C	2009	ALL	Body	Inside Rear View Mirror Module																																																										
C	2009	ALL	Body	Instrument Panel Cluster																																																										
C	2009	ALL	Body	Left Side Object Detection Module																																																										
C	2009	ALL	Body	Lift Gate Module																																																										
C	2009	ALL	Body	Memory Seat Module																																																										
C	2009	ALL	Body	Park Assist Module																																																										
C	2009	ALL	Body	Passenger Door Switch																																																										
C	2009	ALL	Body	Passenger Presence System																																																										
C	2009	ALL	Body	Radio																																																										
C	2009	ALL	Body	Rear Heated Seat Module																																																										
C	2009	ALL	Body	Rear HVAC/RSA																																																										
C	2009	ALL	Body	Right Side Object Detection Module																																																										
C	2009	ALL	Body	Rollover Sensor																																																										
C	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2009	ALL	Body	Theft Deterrent Module																																																										
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	ALL	Chassis	Electronic Brake Control Module																																																										
C	2010	ALL	Chassis	Electronic Suspension Control																																																										
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	ALL	Body	Amplifier (Bose)																																																										
C	2010	ALL	Body	Assist Step Controller																																																										
C	2010	ALL	Body	Body Control Module																																																										
C	2010	ALL	Body	Body Control Module (aux.)																																																										
C	2010	ALL	Body	Digital Radio Receiver																																																										
C	2010	ALL	Body	Driver Door Switch																																																										
C	2010	ALL	Body	HVAC Control Module																																																										
C	2010	ALL	Body	Inside Rear View Mirror Module																																																										
C	2010	ALL	Body	Instrument Panel Cluster																																																										
C	2010	ALL	Body	Left Side Object Detection Module																																																										
C	2010	ALL	Body	Lift Gate Module																																																										
C	2010	ALL	Body	Memory Seat Module																																																										
C	2010	ALL	Body	Park Assist Module																																																										
C	2010	ALL	Body	Passenger Door Switch																																																										
C	2010	ALL	Body	Passenger Presence System																																																										
C	2010	ALL	Body	Radio																																																										
C	2010	ALL	Body	Rear Heated Seat Module																																																										
C	2010	ALL	Body	Rear HVAC/RSA																																																										
C	2010	ALL	Body	Right Side Object Detection Module																																																										
C	2010	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2010	ALL	Body	Theft Deterrent Module																																																										
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																																										
E	2004	ALL	Chassis	Electronic Suspension Control																																																										
E	2004	ALL	Chassis	Tire Pressure Monitor																																																										
E	2004	ALL	Chassis	VES																																																										
E	2004	ALL	Body	Amplifier (Bose)																																																										
E	2004	ALL	Body	Amplifier (Delco)																																																										
E	2004	ALL	Body	Climate Control Panel																																																										
E	2004	ALL	Body	Dash Integration Module																																																										
E	2004	ALL	Body	Disc Player and Video Display																																																										
E	2004	ALL	Body	Driver Door Switch																																																										
E	2004	ALL	Body	Driver Door Module																																																										
E	2004	ALL	Body	Passenger Door Module																																																										
E	2004	ALL	Body	Left Rear Door Module																																																										
E	2004	ALL	Body	Right Rear Door Module																																																										
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2004	ALL	Body	Instrument Panel Cluster																																																										
E	2004	ALL	Body	Memory Seat Module																																																										
E	2004	ALL	Body	OnStar																																																										
E	2004	ALL	Body	Personalization																																																										
E	2004	ALL	Body	Base Radio																																																										
E	2004	ALL	Body	Navigation Radio																																																										
E	2004	ALL	Body	Rear Integration Module																																																										
E	2004	ALL	Body	Rear Seat Module																																																										
E	2004	ALL	Body	Remote Function Actuation																																																										
E	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2004	ALL	Body	TV Antenna Module																																																										
E	2004	ALL	Body	Vehicle Theft Deterrent																																																										
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																																										
E	2005	ALL	Chassis	Electronic Suspension Control																																																										
E	2005	ALL	Chassis	Tire Pressure Monitor																																																										
E	2005	ALL	Chassis	VES																																																										
E	2005	ALL	Body	Amplifier (Bose)																																																										
E	2005	ALL	Body	Amplifier (Delco)																																																										
E	2005	ALL	Body	Climate Control Panel																																																										
E	2005	ALL	Body	Dash Integration Module																																																										
E	2005	ALL	Body	Disc Player and Video Display																																																										
E	2005	ALL	Body	Driver Door Switch																																																										
E	2005	ALL	Body	Driver Door Module																																																										
E	2005	ALL	Body	Passenger Door Module																																																										
E	2005	ALL	Body	Left Rear Door Module																																																										
E	2005	ALL	Body	Right Rear Door Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																											
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																											
E	2005	ALL	Body	Instrument Panel Cluster																																																											
E	2005	ALL	Body	Memory Seat Module																																																											
E	2005	ALL	Body	Personalization																																																											
E	2005	ALL	Body	Base Radio																																																											
E	2005	ALL	Body	Navigation Radio																																																											
E	2005	ALL	Body	Rear Integration Module																																																											
E	2005	ALL	Body	Rear Seat Module																																																											
E	2005	ALL	Body	Remote Function Actuation																																																											
E	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
E	2005	ALL	Body	TV Antenna Module																																																											
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																											
E	2005	ALL	Body	Vehicle Theft Deterrent																																																											
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																											
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																											
E	2006	ALL	Chassis	Electronic Suspension Control																																																											
E	2006	ALL	Chassis	Tire Pressure Monitor																																																											
E	2006	ALL	Chassis	VES																																																											
E	2006	ALL	Body	Amplifier (Bose)																																																											
E	2006	ALL	Body	Amplifier (Delco)																																																											
E	2006	ALL	Body	Climate Control Panel																																																											
E	2006	ALL	Body	Dash Integration Module																																																											
E	2006	ALL	Body	Disc Player and Video Display																																																											
E	2006	ALL	Body	Driver Door Switch																																																											
E	2006	ALL	Body	Driver Door Module																																																											
E	2006	ALL	Body	Passenger Door Module																																																											
E	2006	ALL	Body	Left Rear Door Module																																																											
E	2006	ALL	Body	Right Rear Door Module																																																											
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																											
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																											
E	2006	ALL	Body	Instrument Panel Cluster																																																											
E	2006	ALL	Body	Lift Gate Module																																																											
E	2006	ALL	Body	Memory Seat Module																																																											
E	2006	ALL	Body	Personalization																																																											
E	2006	ALL	Body	Base Radio																																																											
E	2006	ALL	Body	Navigation Radio																																																											
E	2006	ALL	Body	Rear Integration Module																																																											
E	2006	ALL	Body	Rear Seat Module																																																											
E	2006	ALL	Body	Remote Function Actuation																																																											
E	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																											
E	2006	ALL	Body	Vehicle Theft Deterrent																																																											
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																											
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
E	2007	ALL	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
E	2007	ALL	Chassis	Electronic Suspension Control																																																										
E	2007	ALL	Body	Amplifier (Bose)																																																										
E	2007	ALL	Body	Body Control Module																																																										
E	2007	ALL	Body	Body Control Module (aux.)																																																										
E	2007	ALL	Body	Digital Radio Receiver																																																										
E	2007	ALL	Body	Driver Door Switch																																																										
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2007	ALL	Body	HVAC Control Module																																																										
E	2007	ALL	Body	Instrument Panel Cluster																																																										
E	2007	ALL	Body	Lift Gate Module																																																										
E	2007	ALL	Body	Memory Seat Module																																																										
E	2007	ALL	Body	Park Assist Module																																																										
E	2007	ALL	Body	Passenger Door Switch																																																										
E	2007	ALL	Body	Passenger Presence System																																																										
E	2007	ALL	Body	Radio																																																										
E	2007	ALL	Body	Rear HVAC/RSA																																																										
E	2007	ALL	Body	Rear Seat Module																																																										
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																										
E	2007	ALL	Body	Rollover Sensor																																																										
E	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2007	ALL	Body	Theft Deterrent Module																																																										
E	2007	ALL	Body	TV Antenna Module																																																										
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2008	ALL	Chassis	Electronic Brake Control Module																																																										
E	2008	ALL	Chassis	Electronic Suspension Control																																																										
E	2008	ALL	Body	Amplifier (Bose)																																																										
E	2008	ALL	Body	Body Control Module																																																										
E	2008	ALL	Body	Body Control Module (aux.)																																																										
E	2008	ALL	Body	Digital Radio Receiver																																																										
E	2008	ALL	Body	Driver Door Switch																																																										
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2008	ALL	Body	HVAC Control Module																																																										
E	2008	ALL	Body	Instrument Panel Cluster																																																										
E	2008	ALL	Body	Lift Gate Module																																																										
E	2008	ALL	Body	Memory Seat Module																																																										
E	2008	ALL	Body	Park Assist Module																																																										
E	2008	ALL	Body	Passenger Door Switch																																																										
E	2008	ALL	Body	Passenger Presence System																																																										
E	2008	ALL	Body	Radio																																																										
E	2008	ALL	Body	Rear HVAC/RSA																																																										
E	2008	ALL	Body	Rear Seat Module																																																										
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
E	2008	ALL	Body	Rollover Sensor																																																										
E	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2008	ALL	Body	Theft Deterrent Module																																																										
E	2008	ALL	Body	TV Antenna Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2009	ALL	Chassis	Electronic Brake Control Module																																																										
E	2009	ALL	Chassis	Electronic Suspension Control																																																										
E	2009	ALL	Body	Amplifier (Bose)																																																										
E	2009	ALL	Body	Body Control Module																																																										
E	2009	ALL	Body	Body Control Module (aux.)																																																										
E	2009	ALL	Body	Digital Radio Receiver																																																										
E	2009	ALL	Body	Driver Door Switch																																																										
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2009	ALL	Body	HVAC Control Module																																																										
E	2009	ALL	Body	Instrument Panel Cluster																																																										
E	2009	ALL	Body	Lift Gate Module																																																										
E	2009	ALL	Body	Memory Seat Module																																																										
E	2009	ALL	Body	Park Assist Module																																																										
E	2009	ALL	Body	Passenger Door Switch																																																										
E	2009	ALL	Body	Passenger Presence System																																																										
E	2009	ALL	Body	Radio																																																										
E	2009	ALL	Body	Rear HVAC/RSA																																																										
E	2009	ALL	Body	Rear Seat Module																																																										
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
E	2009	ALL	Body	Rollover Sensor																																																										
E	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2009	ALL	Body	Theft Deterrent Module																																																										
E	2009	ALL	Body	TV Antenna Module																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2004	ALL	Chassis	ESC																																																										
K	2004	ALL	Chassis	Rear Wheel Steering																																																										
K	2004	ALL	Chassis	Tire Pressure Monitor																																																										
K	2004	ALL	Chassis	VSES																																																										
K	2004	ALL	Body	Amplifier (Bose)																																																										
K	2004	ALL	Body	Body Control Module																																																										
K	2004	ALL	Body	CD Changer																																																										
K	2004	ALL	Body	Chime																																																										
K	2004	ALL	Body	Driver Door Module																																																										
K	2004	ALL	Body	Driver Seat Module																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2004	ALL	Body	Instrument Panel Cluster																																																										
K	2004	ALL	Body	OnStar																																																										
K	2004	ALL	Body	Passenger Door Module																																																										
K	2004	ALL	Body	Passenger Presence System																																																										
K	2004	ALL	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2004	ALL	Body	Uplevel Radio																																																											
K	2004	ALL	Body	Navigation Radio																																																											
K	2004	ALL	Body	Rear Aux. Climate Module																																																												
K	2004	ALL	Body	Rear HVAC																																																												
K	2004	ALL	Body	Rear Seat Audio																																																												
K	2004	ALL	Body	Rear Seat Entertainment																																																												
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																												
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																												
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2005	ALL	Chassis	ESC																																																											
K	2005	ALL	Chassis	Rear Wheel Steering																																																												
K	2005	ALL	Chassis	Tire Pressure Monitor																																																												
K	2005	ALL	Chassis	VSES																																																												
K	2005	ALL	Body	Amplifier (Bose)																																																												
K	2005	ALL	Body	Body Control Module																																																												
K	2005	ALL	Body	CD Changer																																																												
K	2005	ALL	Body	Chime																																																												
K	2005	ALL	Body	Disc Player and Video Display																																																												
K	2005	ALL	Body	Driver Door Module																																																												
K	2005	ALL	Body	Driver Seat Module																																																												
K	2005	ALL	Body	Generator Battery Control Module																																																												
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2005	ALL	Body	Instrument Panel Cluster																																																												
K	2005	ALL	Body	Passenger Door Module																																																												
K	2005	ALL	Body	Passenger Presence System																																																												
K	2005	ALL	Body	Base Radio																																																												
K	2005	ALL	Body	Uplevel Radio																																																												
K	2005	ALL	Body	Navigation Radio																																																												
K	2005	ALL	Body	Rear Aux. Climate Module																																																												
K	2005	ALL	Body	Rear HVAC																																																												
K	2005	ALL	Body	Rear Seat Audio																																																												
K	2005	ALL	Body	Remote Function Actuation																																																												
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																												
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																												
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2006	ALL	Chassis	ESC																																																											
K	2006	ALL	Chassis	Tire Pressure Monitor																																																												
K	2006	ALL	Chassis	VSES																																																												
K	2006	ALL	Body	Amplifier (Bose)																																																												
K	2006	ALL	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2006	ALL	Body	CD Changer																																																										
K	2006	ALL	Body	Chime																																																										
K	2006	ALL	Body	Disc Player and Video Display																																																										
K	2006	ALL	Body	Driver Door Module																																																										
K	2006	ALL	Body	Driver Seat Module																																																										
K	2006	ALL	Body	Generator Battery Control Module																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2006	ALL	Body	Instrument Panel Cluster																																																										
K	2006	ALL	Body	Passenger Door Module																																																										
K	2006	ALL	Body	Passenger Presence System																																																										
K	2006	ALL	Body	Base Radio																																																										
K	2006	ALL	Body	Uplevel Radio																																																										
K	2006	ALL	Body	Navigation Radio																																																										
K	2006	ALL	Body	Rear Aux. Climate Module																																																										
K	2006	ALL	Body	Rear HVAC																																																										
K	2006	ALL	Body	Rear Seat Audio																																																										
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2007	ALL	Chassis	Electronic Brake Control Module																																																										
K	2007	ALL	Chassis	Electronic Suspension Control																																																										
K	2007	ALL	Body	Amplifier (Bose)																																																										
K	2007	ALL	Body	Assist Step Controller																																																										
K	2007	ALL	Body	Body Control Module																																																										
K	2007	ALL	Body	Body Control Module (aux.)																																																										
K	2007	ALL	Body	Digital Radio Receiver																																																										
K	2007	ALL	Body	Driver Door Switch																																																										
K	2007	ALL	Body	HVAC Control Module																																																										
K	2007	ALL	Body	Inside Rear View Mirror Module																																																										
K	2007	ALL	Body	Instrument Panel Cluster																																																										
K	2007	ALL	Body	Lift Gate Module																																																										
K	2007	ALL	Body	Memory Seat Module																																																										
K	2007	ALL	Body	Park Assist Module																																																										
K	2007	ALL	Body	Passenger Door Switch																																																										
K	2007	ALL	Body	Passenger Presence System																																																										
K	2007	ALL	Body	Radio																																																										
K	2007	ALL	Body	Rear Heated Seat Module																																																										
K	2007	ALL	Body	Rear HVAC/RSA																																																										
K	2007	ALL	Body	Rollover Sensor																																																										
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2007	ALL	Body	Theft Deterrent Module																																																										
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	ALL	Chassis	Electronic Brake Control Module																																																										
K	2008	ALL	Chassis	Electronic Suspension Control																																																										
K	2008	ALL	Chassis	Trailer Brake Control Module																																																										
K	2008	ALL	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2008	ALL	Body	Assist Step Controller																																																										
K	2008	ALL	Body	Body Control Module																																																										
K	2008	ALL	Body	Body Control Module (aux.)																																																										
K	2008	ALL	Body	Digital Radio Receiver																																																										
K	2008	ALL	Body	Driver Door Switch																																																										
K	2008	ALL	Body	HVAC Control Module																																																										
K	2008	ALL	Body	Inside Rear View Mirror Module																																																										
K	2008	ALL	Body	Instrument Panel Cluster																																																										
K	2008	ALL	Body	Lift Gate Module																																																										
K	2008	ALL	Body	Memory Seat Module																																																										
K	2008	ALL	Body	Park Assist Module																																																										
K	2008	ALL	Body	Passenger Door Switch																																																										
K	2008	ALL	Body	Passenger Presence System																																																										
K	2008	ALL	Body	Radio																																																										
K	2008	ALL	Body	Rear Heated Seat Module																																																										
K	2008	ALL	Body	Rear HVAC/RSA																																																										
K	2008	ALL	Body	Rollover Sensor																																																										
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2008	ALL	Body	Theft Deterrent Module																																																										
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	ALL	Chassis	Electronic Brake Control Module																																																										
K	2009	ALL	Chassis	Electronic Suspension Control																																																										
K	2009	ALL	Chassis	Trailer Brake Control Module																																																										
K	2009	ALL	Body	Amplifier (Bose)																																																										
K	2009	ALL	Body	Assist Step Controller																																																										
K	2009	ALL	Body	Body Control Module																																																										
K	2009	ALL	Body	Body Control Module (aux.)																																																										
K	2009	ALL	Body	Digital Radio Receiver																																																										
K	2009	ALL	Body	Driver Door Switch																																																										
K	2009	ALL	Body	HVAC Control Module																																																										
K	2009	ALL	Body	Inside Rear View Mirror Module																																																										
K	2009	ALL	Body	Instrument Panel Cluster																																																										
K	2009	ALL	Body	Left Side Object Detection Module																																																										
K	2009	ALL	Body	Lift Gate Module																																																										
K	2009	ALL	Body	Memory Seat Module																																																										
K	2009	ALL	Body	Park Assist Module																																																										
K	2009	ALL	Body	Passenger Door Switch																																																										
K	2009	ALL	Body	Passenger Presence System																																																										
K	2009	ALL	Body	Radio																																																										
K	2009	ALL	Body	Rear Heated Seat Module																																																										
K	2009	ALL	Body	Rear HVAC/RSA																																																										
K	2009	ALL	Body	Right Side Object Detection Module																																																										
K	2009	ALL	Body	Rollover Sensor																																																										
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2009	ALL	Body	Theft Deterrent Module																																																										
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	ALL	Chassis	Electronic Brake Control Module																																																												
K	2010	ALL	Chassis	Electronic Suspension Control																																																												
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	ALL	Body	Amplifier (Bose)																																																												
K	2010	ALL	Body	Assist Step Controller																																																												
K	2010	ALL	Body	Body Control Module																																																												
K	2010	ALL	Body	Body Control Module (aux.)																																																												
K	2010	ALL	Body	Digital Radio Receiver																																																												
K	2010	ALL	Body	Driver Door Switch																																																												
K	2010	ALL	Body	HVAC Control Module																																																												
K	2010	ALL	Body	Inside Rear View Mirror Module																																																												
K	2010	ALL	Body	Instrument Panel Cluster																																																												
K	2010	ALL	Body	Left Side Object Detection Module																																																												
K	2010	ALL	Body	Lift Gate Module																																																												
K	2010	ALL	Body	Memory Seat Module																																																												
K	2010	ALL	Body	Park Assist Module																																																												
K	2010	ALL	Body	Passenger Door Switch																																																												
K	2010	ALL	Body	Passenger Presence System																																																												
K	2010	ALL	Body	Radio																																																												
K	2010	ALL	Body	Rear Heated Seat Module																																																												
K	2010	ALL	Body	Rear HVAC/RSA																																																												
K	2010	ALL	Body	Right Side Object Detection Module																																																												
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2010	ALL	Body	Theft Deterrent Module																																																												
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																												
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																												
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																												
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																												
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2010	SRX	Chassis	Electronic Brake Control Module																																																												
N	2010	SRX	Chassis	Parking Brake Control Module																																																												
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2010	SRX	Chassis	Suspension Control Module																																																												
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2010	SRX	Body	Passenger Presence Module																																																												
N	2010	SRX	Body	Instrument Cluster																																																												
N	2010	SRX	Body	Headlamp Control Module																																																												
N	2010	SRX	Body	Trailer Interface Control Module																																																												
N	2010	SRX	Body	Radio																																																												
N	2010	SRX	Body	Rear Audio Control Module																																																												
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																												
N	2010	SRX	Body	Multimedia Player Interface Module																																																												
N	2010	SRX	Body	Mobile Telephone Control Module																																																												
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2010	SRX	Body	Liftgate Control Module																																																										
N	2010	SRX	Body	Seat Memory Control Module																										V																																
N	2010	SRX	Body	Front Seat Heating Control Module																																																										
N	2010	SRX	Body	Rear Seat Heating Control Module																																																										
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2010	SRX	Body	Parking Assist Control Module																																																										
N	2010	SRX	Body	Steering Column Lock Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2011	SRX	Chassis	Electronic Brake Control Module																																																										
N	2011	SRX	Chassis	Parking Brake Control Module																																																										
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2011	SRX	Chassis	Suspension Control Module																																																										
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2011	SRX	Body	Passenger Presence Module																																																										
N	2011	SRX	Body	Instrument Cluster																																																										
N	2011	SRX	Body	Headlamp Control Module																																																										
N	2011	SRX	Body	Trailer Interface Control Module																																																										
N	2011	SRX	Body	Radio																																																										
N	2011	SRX	Body	Rear Audio Control Module																																																										
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2011	SRX	Body	Multimedia Player Interface Module																																																										
N	2011	SRX	Body	Mobile Telephone Control Module																																																										
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2011	SRX	Body	Liftgate Control Module																																																										
N	2011	SRX	Body	Seat Memory Control Module																																																										
N	2011	SRX	Body	Front Seat Heating Control Module																																																										
N	2011	SRX	Body	Rear Seat Heating Control Module																																																										
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2011	SRX	Body	Parking Assist Control Module																																																										
N	2011	SRX	Body	Steering Column Lock Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																											
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2012	SRX	Chassis	Electronic Brake Control Module																																																												
N	2012	SRX	Chassis	Parking Brake Control Module																																																												
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2012	SRX	Chassis	Suspension Control Module																																																												
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2012	SRX	Body	Passenger Presence Module																																																												
N	2012	SRX	Body	Instrument Cluster																																																												
N	2012	SRX	Body	Headlamp Control Module																																																												
N	2012	SRX	Body	Trailer Interface Control Module																																																												
N	2012	SRX	Body	Radio																																																												
N	2012	SRX	Body	Rear Audio Control Module																																																												
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																												
N	2012	SRX	Body	Multimedia Player Interface Module																																																												
N	2012	SRX	Body	Mobile Telephone Control Module																																																												
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																																												
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																																												
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																												
N	2012	SRX	Body	Liftgate Control Module																																																												
N	2012	SRX	Body	Seat Memory Control Module																																																												
N	2012	SRX	Body	Front Seat Heating Control Module																																																												
N	2012	SRX	Body	Rear Seat Heating Control Module																																																												
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																												
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																												
N	2012	SRX	Body	Parking Assist Control Module																																																												
N	2012	SRX	Body	Steering Column Lock Control Module																																																												
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2013	SRX	Chassis	Electronic Brake Control Module																																																												
N	2013	SRX	Chassis	Parking Brake Control Module																																																												
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2013	SRX	Chassis	Suspension Control Module																																																												
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2013	SRX	Body	Passenger Presence Module																																																												
N	2013	SRX	Body	Instrument Cluster																																																												
N	2013	SRX	Body	Radio/HVAC Control																																																												
N	2013	SRX	Body	Active Safety Control Module																																																												
N	2013	SRX	Body	Headlamp Control Module																																																												
N	2013	SRX	Body	Trailer Interface Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
N	2013	SRX	Body	Radio																																																										
N	2013	SRX	Body	Amplifier																																																										
N	2013	SRX	Body	Media Disc Player																																																										
N	2013	SRX	Body	Human Machine Interface Control Module																																																										
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2013	SRX	Body	Liftgate Control Module																																																										
N	2013	SRX	Body	Seat Memory Control Module																																																										
N	2013	SRX	Body	Rear Seat Heating Control Module																																																										
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2013	SRX	Body	Right Side Object Detection Control Module																																																										
N	2013	SRX	Body	Left Side Object Detection Control Module																																																										
N	2013	SRX	Body	Parking Assist Control Module																																																										
N	2013	SRX	Body	Frontview Camera Module																																																										
N	2013	SRX	Body	Steering Column Lock Control Module																																																										
N	2013	SRX	Body	Long Range Radar Sensor Module																																																										
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																										
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2014	SRX	Chassis	Electronic Brake Control Module																																																										
N	2014	SRX	Chassis	Parking Brake Control Module																																																										
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2014	SRX	Chassis	Suspension Control Module																																																										
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2014	SRX	Body	Passenger Presence Module																																																										
N	2014	SRX	Body	Instrument Cluster																																																										
N	2014	SRX	Body	Radio/HVAC Control																																																										
N	2014	SRX	Body	Active Safety Control Module																																																										
N	2014	SRX	Body	Headlamp Control Module																																																										
N	2014	SRX	Body	Trailer Interface Control Module																																																										
N	2014	SRX	Body	Radio																																																										
N	2014	SRX	Body	Amplifier																																																										
N	2014	SRX	Body	Media Disc Player																																																										
N	2014	SRX	Body	Human Machine Interface Control Module																																																										
N	2014	SRX	Body	Navigation Control Module																																																										
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																										
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2014	SRX	Body	Liftgate Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2014	SRX	Body	Rear Seat Heating Control Module																																																										
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2014	SRX	Body	Right Side Object Detection Control Module																																																										
N	2014	SRX	Body	Left Side Object Detection Control Module																																																										
N	2014	SRX	Body	Parking Assist Control Module																																																										
N	2014	SRX	Body	Frontview Camera Module																																																										
N	2014	SRX	Body	Steering Column Lock Control Module																																																										
N	2014	SRX	Body	Long Range Radar Sensor Module																																																										
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																										
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2015	SRX	Chassis	Electronic Brake Control Module																																																										
N	2015	SRX	Chassis	Parking Brake Control Module																																																										
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2015	SRX	Chassis	Suspension Control Module																																																										
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2015	SRX	Body	Passenger Presence Module																																																										
N	2015	SRX	Body	Instrument Cluster																																																										
N	2015	SRX	Body	Radio/HVAC Control																																																										
N	2015	SRX	Body	Active Safety Control Module																																																										
N	2015	SRX	Body	Headlamp Control Module																																																										
N	2015	SRX	Body	Trailer Interface Control Module																																																										
N	2015	SRX	Body	Radio																																																										
N	2015	SRX	Body	Amplifier																																																										
N	2015	SRX	Body	Rear Audio Control Module																																																										
N	2015	SRX	Body	Media Disc Player																																																										
N	2015	SRX	Body	Human Machine Interface Control Module																																																										
N	2015	SRX	Body	Navigation Control Module																																																										
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																										
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2015	SRX	Body	Liftgate Control Module																																																										
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2015	SRX	Body	Rear Seat Heating Control Module																																																										
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2015	SRX	Body	Right Side Object Detection Control Module																																																										
N	2015	SRX	Body	Left Side Object Detection Control Module																																																										
N	2015	SRX	Body	Parking Assist Control Module																																																										
N	2015	SRX	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
N	2015	SRX	Body	Steering Column Lock Control Module																																																										
N	2015	SRX	Body	Long Range Radar Sensor Module																																																										
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																										
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2016	SRX	Chassis	Electronic Brake Control Module																																																										
N	2016	SRX	Chassis	Parking Brake Control Module																																																										
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2016	SRX	Chassis	Suspension Control Module																																																										
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2016	SRX	Body	Passenger Presence Module																																																										
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																																										
N	2016	SRX	Body	Radio/HVAC Control																																																										
N	2016	SRX	Body	Active Safety Control Module																																																										
N	2016	SRX	Body	Headlamp Control Module																																																										
N	2016	SRX	Body	Trailer Interface Control Module																																																										
N	2016	SRX	Body	Radio																																																										
N	2016	SRX	Body	Amplifier																																																										
N	2016	SRX	Body	Rear Audio Control Module																																																										
N	2016	SRX	Body	Media Disc Player																																																										
N	2016	SRX	Body	Human Machine Interface Control Module																																																										
N	2016	SRX	Body	Navigation Control Module																																																										
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																										
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2016	SRX	Body	Liftgate Control Module																																																										
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2016	SRX	Body	Rear Seat Heating Control Module																																																										
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2016	SRX	Body	Right Side Object Detection Control Module																																																										
N	2016	SRX	Body	Left Side Object Detection Control Module																																																										
N	2016	SRX	Body	Parking Assist Control Module																																																										
N	2016	SRX	Body	Frontview Camera Module																																																										
N	2016	SRX	Body	Steering Column Lock Control Module																																																										
N	2016	SRX	Body	Long Range Radar Sensor Module																																																										
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																										
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
3	2011	ALL	Chassis	Electronic Brake Control Module																																																										
3	2011	ALL	Chassis	Electronic Suspension Control																																																										
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2011	ALL	Body	Amplifier (Bose)																																																										
3	2011	ALL	Body	Assist Step Controller																																																										
3	2011	ALL	Body	Body Control Module																																																										
3	2011	ALL	Body	Body Control Module (aux.)																																																										
3	2011	ALL	Body	Digital Radio Receiver																																																										
3	2011	ALL	Body	Driver Door Switch																																																										
3	2011	ALL	Body	HVAC Control Module																																																										
3	2011	ALL	Body	Inside Rear View Mirror Module																																																										
3	2011	ALL	Body	Instrument Panel Cluster																																																										
3	2011	ALL	Body	Left Side Object Detection Module																																																										
3	2011	ALL	Body	Lift Gate Module																																																										
3	2011	ALL	Body	Memory Seat Module																																																										
3	2011	ALL	Body	Park Assist Module																																																										
3	2011	ALL	Body	Passenger Door Switch																																																										
3	2011	ALL	Body	Passenger Presence System																																																										
3	2011	ALL	Body	Radio																																																										
3	2011	ALL	Body	Rear Heated Seat Module																																																										
3	2011	ALL	Body	Rear HVAC/RSA																																																										
3	2011	ALL	Body	Right Side Object Detection Module																																																										
3	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
3	2011	ALL	Body	Theft Deterrent Module																																																										
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
3	2012	ALL	Chassis	Electronic Brake Control Module																																																										
3	2012	ALL	Chassis	Electronic Suspension Control																																																										
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2012	ALL	Body	Amplifier (Bose)																																																										
3	2012	ALL	Body	Assist Step Controller																																																										
3	2012	ALL	Body	Body Control Module																																																										
3	2012	ALL	Body	Body Control Module (aux.)																																																										
3	2012	ALL	Body	Driver Door Switch																																																										
3	2012	ALL	Body	HVAC Control Module																																																										
3	2012	ALL	Body	Inside Rear View Mirror Module																																																										
3	2012	ALL	Body	Instrument Panel Cluster																																																										
3	2012	ALL	Body	Left Side Object Detection Module																																																										
3	2012	ALL	Body	Lift Gate Module																																																										
3	2012	ALL	Body	Memory Seat Module																																																										
3	2012	ALL	Body	Park Assist Module																																																										
3	2012	ALL	Body	Passenger Door Switch																																																										
3	2012	ALL	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
3	2012	ALL	Body	Radio																																																										
3	2012	ALL	Body	Rear Heated Seat Module																																																										
3	2012	ALL	Body	Rear HVAC/RSA																																																										
3	2012	ALL	Body	Right Side Object Detection Module																																																										
3	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
3	2012	ALL	Body	Theft Deterrent Module																																																										
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
3	2013	ALL	Chassis	Electronic Brake Control Module																																																										
3	2013	ALL	Chassis	Electronic Suspension Control																																																										
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2013	ALL	Body	Amplifier (Bose)																																																										
3	2013	ALL	Body	Assist Step Controller																																																										
3	2013	ALL	Body	Body Control Module																																																										
3	2013	ALL	Body	Body Control Module (aux.)																																																										
3	2013	ALL	Body	Driver Door Switch																																																										
3	2013	ALL	Body	HVAC Control Module																																																										
3	2013	ALL	Body	Inside Rear View Mirror Module																																																										
3	2013	ALL	Body	Instrument Panel Cluster																																																										
3	2013	ALL	Body	Left Side Object Detection Module																																																										
3	2013	ALL	Body	Lift Gate Module																																																										
3	2013	ALL	Body	Memory Seat Module																																																										
3	2013	ALL	Body	Park Assist Module																																																										
3	2013	ALL	Body	Passenger Door Switch																																																										
3	2013	ALL	Body	Passenger Presence System																																																										
3	2013	ALL	Body	Radio																																																										
3	2013	ALL	Body	Rear Heated Seat Module																																																										
3	2013	ALL	Body	Rear HVAC/RSA																																																										
3	2013	ALL	Body	Right Side Object Detection Module																																																										
3	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
3	2013	ALL	Body	Theft Deterrent Module																																																										
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																										
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2014	Escalade	Chassis	Suspension Control Module																																																										
3	2014	Escalade	Body	Body Control Module																																																										
3	2014	Escalade	Body	Auxiliary Body Control Module																																																										
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2014	Escalade	Body	Passenger Presence Module																																																										
3	2014	Escalade	Body	Instrument Cluster																																																										
3	2014	Escalade	Body	Radio																																																										
3	2014	Escalade	Body	Amplifier																																																										
3	2014	Escalade	Body	Rear Audio Control Module																																																										
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																										
3	2014	Escalade	Body	Personal Audio Link Control Module																																																										
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																										
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
3	2014	Escalade	Body	HVAC Control Module																												V																																
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																											
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																											
3	2014	Escalade	Body	Liftgate Control Module																																																											
3	2014	Escalade	Body	Seat Memory Control Module																																																											
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																											
3	2014	Escalade	Body	Assist Step Control Module																																																											
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																											
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																											
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																											
3	2014	Escalade	Body	Parking Assist Control Module																				V																																								
3	2014	Escalade	Body	Theft Deterrent Module																																																												
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																												
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																												
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																												
3	2014	Escalade ESV	Body	Body Control Module																																																												
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																												
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
3	2014	Escalade ESV	Body	Passenger Presence Module																																																												
3	2014	Escalade ESV	Body	Instrument Cluster																																																												
3	2014	Escalade ESV	Body	Radio																																																												
3	2014	Escalade ESV	Body	Amplifier																																																												
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																												
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																												
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																												
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																												
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																												
3	2014	Escalade ESV	Body	HVAC Control Module																												V																																
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																												
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																												
3	2014	Escalade ESV	Body	Liftgate Control Module																																																												
3	2014	Escalade ESV	Body	Seat Memory Control Module																																																												
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																												
3	2014	Escalade ESV	Body	Assist Step Control Module																																																												
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																												
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																												
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																												
3	2014	Escalade ESV	Body	Parking Assist Control Module																				V																																								
3	2014	Escalade ESV	Body	Theft Deterrent Module																																																												
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																											
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																											
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																										
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																										
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																										
3	2015	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2015	Escalade	Chassis	Parking Brake Control Module																																																										
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2015	Escalade	Chassis	Power Steering Control Module																																																										
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2015	Escalade	Chassis	Suspension Control Module																																																										
3	2015	Escalade	Body	Body Control Module																																																										
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2015	Escalade	Body	Passenger Presence Module																																																										
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2015	Escalade	Body	Instrument Cluster																																																										
3	2015	Escalade	Body	Radio/HVAC Control																																																										
3	2015	Escalade	Body	Active Safety Control Module																																																										
3	2015	Escalade	Body	Video Processing Control Module																																																										
3	2015	Escalade	Body	Radio																																																										
3	2015	Escalade	Body	Amplifier																																																										
3	2015	Escalade	Body	Media Disc Player																																																										
3	2015	Escalade	Body	Human Machine Interface Control Module																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2015	Escalade	Body	HVAC Control Module																																																										
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																										
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																										
3	2015	Escalade	Body	Keyless Entry Control Module																																																										
3	2015	Escalade	Body	Assist Step Control Module																																																										
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																										
3	2015	Escalade	Body	Parking Assist Control Module																																																										
3	2015	Escalade	Body	Frontview Camera Module																																																										
3	2015	Escalade	Body	Steering Column Lock Control Module																																																										
3	2015	Escalade	Body	Battery Energy Control Module																																																										
3	2015	Escalade	Body	Long Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																										
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																																										
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2015	Escalade ESV	Body	Body Control Module																																																										
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2015	Escalade ESV	Body	Passenger Presence Module																																																										
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2015	Escalade ESV	Body	Instrument Cluster																																																										
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																										
3	2015	Escalade ESV	Body	Active Safety Control Module																																																										
3	2015	Escalade ESV	Body	Video Processing Control Module																																																										
3	2015	Escalade ESV	Body	Radio																																																										
3	2015	Escalade ESV	Body	Amplifier																																																										
3	2015	Escalade ESV	Body	Media Disc Player																																																										
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2015	Escalade ESV	Body	HVAC Control Module																																																										
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																										
3	2015	Escalade ESV	Body	Assist Step Control Module																																																										
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2015	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2015	Escalade ESV	Body	Frontview Camera Module																																																										
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																										
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2016	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2016	Escalade	Chassis	Parking Brake Control Module																																																										
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2016	Escalade	Chassis	Power Steering Control Module																																																										
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2016	Escalade	Chassis	Suspension Control Module																																																										
3	2016	Escalade	Body	Body Control Module																																																										
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
3	2016	Escalade	Body	Passenger Presence Module																																																										
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2016	Escalade	Body	Instrument Cluster																																																										
3	2016	Escalade	Body	Radio/HVAC Control																																																										
3	2016	Escalade	Body	Active Safety Control Module																																																										
3	2016	Escalade	Body	Video Processing Control Module																																																										
3	2016	Escalade	Body	Radio																																																										
3	2016	Escalade	Body	Amplifier																																																										
3	2016	Escalade	Body	Media Disc Player																																																										
3	2016	Escalade	Body	Human Machine Interface Control Module																																																										
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																																										
3	2016	Escalade	Body	HVAC Control Module																																																										
3	2016	Escalade	Body	Liftgate Control Module																																																										
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																										
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																										
3	2016	Escalade	Body	Keyless Entry Control Module																																																										
3	2016	Escalade	Body	Assist Step Control Module																																																										
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																										
3	2016	Escalade	Body	Parking Assist Control Module																																																										
3	2016	Escalade	Body	Frontview Camera Module																																																										
3	2016	Escalade	Body	Steering Column Lock Control Module																																																										
3	2016	Escalade	Body	Long Range Radar Sensor Module																																																										
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																										
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																																										
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2016	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2016	Escalade ESV	Body	Body Control Module																																																										
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2016	Escalade ESV	Body	Passenger Presence Module																																																										
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2016	Escalade ESV	Body	Instrument Cluster																																																										
3	2016	Escalade ESV	Body	Radio Control																																																										
3	2016	Escalade ESV	Body	HVAC Control																																																										
3	2016	Escalade ESV	Body	Active Safety Control Module																																																										
3	2016	Escalade ESV	Body	Video Processing Control Module																																																										
3	2016	Escalade ESV	Body	Radio																																																										
3	2016	Escalade ESV	Body	Amplifier																																																										
3	2016	Escalade ESV	Body	Media Disc Player																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																										
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																										
3	2016	Escalade ESV	Body	HVAC Control Module																																																										
3	2016	Escalade ESV	Body	Liftgate Control Module																																																										
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																										
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																										
3	2016	Escalade ESV	Body	Assist Step Control Module																																																										
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2016	Escalade ESV	Body	Frontview Camera Module																																																										
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																										
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
4	2011	ALL	Chassis	Electronic Brake Control Module																																																										
4	2011	ALL	Chassis	Electronic Suspension Control																																																										
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																										
4	2011	ALL	Body	Amplifier (Bose)																																																										
4	2011	ALL	Body	Assist Step Controller																																																										
4	2011	ALL	Body	Body Control Module																																																										
4	2011	ALL	Body	Body Control Module (aux.)																																																										
4	2011	ALL	Body	Driver Door Switch																																																										
4	2011	ALL	Body	HVAC Control Module																																																										
4	2011	ALL	Body	Inside Rear View Mirror Module																																																										
4	2011	ALL	Body	Instrument Panel Cluster																																																										
4	2011	ALL	Body	Left Side Object Detection Module																																																										
4	2011	ALL	Body	Lift Gate Module																																																										
4	2011	ALL	Body	Memory Seat Module																																																										
4	2011	ALL	Body	Park Assist Module																																																										
4	2011	ALL	Body	Passenger Door Switch																																																										
4	2011	ALL	Body	Passenger Presence System																																																										
4	2011	ALL	Body	Radio																																																										
4	2011	ALL	Body	Rear Heated Seat Module																																																										
4	2011	ALL	Body	Rear HVAC/RSA																																																										
4	2011	ALL	Body	Right Side Object Detection Module																																																										
4	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
4	2011	ALL	Body	Theft Deterrent Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module
4	2012	ALL	Chassis	Electronic Brake Control Module
4	2012	ALL	Chassis	Electronic Suspension Control
4	2012	ALL	Chassis	FPCM with Trailer Brake Control
4	2012	ALL	Body	Amplifier (Bose)
4	2012	ALL	Body	Assist Step Controller
4	2012	ALL	Body	Body Control Module
4	2012	ALL	Body	Body Control Module (aux.)
4	2012	ALL	Body	Driver Door Switch
4	2012	ALL	Body	HVAC Control Module
4	2012	ALL	Body	Inside Rear View Mirror Module
4	2012	ALL	Body	Instrument Panel Cluster
4	2012	ALL	Body	Left Side Object Detection Module
4	2012	ALL	Body	Lift Gate Module
4	2012	ALL	Body	Memory Seat Module
4	2012	ALL	Body	Park Assist Module
4	2012	ALL	Body	Passenger Door Switch
4	2012	ALL	Body	Passenger Presence System
4	2012	ALL	Body	Radio
4	2012	ALL	Body	Rear Heated Seat Module
4	2012	ALL	Body	Rear HVAC/RSA
4	2012	ALL	Body	Right Side Object Detection Module
4	2012	ALL	Body	Supplemental Inflatable Restraint
4	2012	ALL	Body	Theft Deterrent Module
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module
4	2013	ALL	Chassis	Electronic Brake Control Module
4	2013	ALL	Chassis	Electronic Suspension Control
4	2013	ALL	Chassis	FPCM with Trailer Brake Control
4	2013	ALL	Chassis	FPCM with Trailer Brake Control
4	2013	ALL	Body	Amplifier (Bose)
4	2013	ALL	Body	Assist Step Controller
4	2013	ALL	Body	Body Control Module
4	2013	ALL	Body	Body Control Module (aux.)
4	2013	ALL	Body	Driver Door Switch
4	2013	ALL	Body	HVAC Control Module
4	2013	ALL	Body	Inside Rear View Mirror Module
4	2013	ALL	Body	Instrument Panel Cluster
4	2013	ALL	Body	Left Side Object Detection Module
4	2013	ALL	Body	Lift Gate Module
4	2013	ALL	Body	Memory Seat Module
4	2013	ALL	Body	Park Assist Module
4	2013	ALL	Body	Passenger Door Switch
4	2013	ALL	Body	Passenger Presence System
4	2013	ALL	Body	Radio
4	2013	ALL	Body	Rear Heated Seat Module
4	2013	ALL	Body	Rear HVAC/RSA
4	2013	ALL	Body	Right Side Object Detection Module
4	2013	ALL	Body	Supplemental Inflatable Restraint
4	2013	ALL	Body	Theft Deterrent Module

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade	Chassis	Suspension Control Module																																																										
4	2014	Escalade	Body	Body Control Module																																																										
4	2014	Escalade	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2014	Escalade	Body	Passenger Presence Module																																																										
4	2014	Escalade	Body	Instrument Cluster																																																										
4	2014	Escalade	Body	Radio																																																										
4	2014	Escalade	Body	Amplifier																																																										
4	2014	Escalade	Body	Rear Audio Control Module																																																										
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2014	Escalade	Body	HVAC Control Module																											V																															
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Liftgate Control Module																																																										
4	2014	Escalade	Body	Seat Memory Control Module																																																										
4	2014	Escalade	Body	Rear Seat Heating Control Module																																																										
4	2014	Escalade	Body	Assist Step Control Module																																																										
4	2014	Escalade	Body	Right Side Object Detection Control Module																																																										
4	2014	Escalade	Body	Left Side Object Detection Control Module																																																										
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																																										
4	2014	Escalade	Body	Parking Assist Control Module																				V																																						
4	2014	Escalade	Body	Theft Deterrent Module																																																										
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2014	Escalade ESV	Body	Body Control Module																																																										
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2014	Escalade ESV	Body	Passenger Presence Module																																																										
4	2014	Escalade ESV	Body	Instrument Cluster																																																										
4	2014	Escalade ESV	Body	Radio																																																										
4	2014	Escalade ESV	Body	Amplifier																																																										
4	2014	Escalade ESV	Body	Rear Audio Control Module																																																										
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2014	Escalade ESV	Body	HVAC Control Module																											V																															
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																										
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
4	2014	Escalade ESV	Body	Liftgate Control Module																																																												
4	2014	Escalade ESV	Body	Seat Memory Control Module																																																												
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																												
4	2014	Escalade ESV	Body	Assist Step Control Module																																																												
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																												
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																												
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																												
4	2014	Escalade ESV	Body	Parking Assist Control Module																				V																																								
4	2014	Escalade ESV	Body	Theft Deterrent Module																																																												
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																												
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																												
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																												
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																												
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																												
4	2015	Escalade	Chassis	Electronic Brake Control Module																																																												
4	2015	Escalade	Chassis	Parking Brake Control Module																																																												
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																												
4	2015	Escalade	Chassis	Power Steering Control Module																																																												
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																												
4	2015	Escalade	Chassis	Suspension Control Module																																																												
4	2015	Escalade	Body	Body Control Module																																																												
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
4	2015	Escalade	Body	Passenger Presence Module																																																												
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																												
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																												
4	2015	Escalade	Body	Instrument Cluster																																																												
4	2015	Escalade	Body	Radio/HVAC Control																																																												
4	2015	Escalade	Body	Active Safety Control Module																																																												
4	2015	Escalade	Body	Video Processing Control Module																																																												
4	2015	Escalade	Body	Radio																																																												
4	2015	Escalade	Body	Amplifier																																																												
4	2015	Escalade	Body	Media Disc Player																																																												
4	2015	Escalade	Body	Human Machine Interface Control Module																																																												
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																												
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																												
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																												
4	2015	Escalade	Body	HVAC Control Module																																																												
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																											
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																											
4	2015	Escalade	Body	Keyless Entry Control Module																																																											
4	2015	Escalade	Body	Assist Step Control Module																																																											
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
4	2015	Escalade	Body	Parking Assist Control Module																																																										
4	2015	Escalade	Body	Frontview Camera Module																																																										
4	2015	Escalade	Body	Steering Column Lock Control Module																																																										
4	2015	Escalade	Body	Battery Energy Control Module																																																										
4	2015	Escalade	Body	Long Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																										
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																																										
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2015	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2015	Escalade ESV	Body	Body Control Module																																																										
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2015	Escalade ESV	Body	Passenger Presence Module																																																										
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2015	Escalade ESV	Body	Instrument Cluster																																																										
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																										
4	2015	Escalade ESV	Body	Active Safety Control Module																																																										
4	2015	Escalade ESV	Body	Video Processing Control Module																																																										
4	2015	Escalade ESV	Body	Radio																																																										
4	2015	Escalade ESV	Body	Amplifier																																																										
4	2015	Escalade ESV	Body	Media Disc Player																																																										
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2015	Escalade ESV	Body	HVAC Control Module																																																										
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																										
4	2015	Escalade ESV	Body	Assist Step Control Module																																																										
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
4	2015	Escalade ESV	Body	Parking Assist Control Module																																																										
4	2015	Escalade ESV	Body	Frontview Camera Module																																																										
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
4	2016	Escalade	Chassis	Electronic Brake Control Module																																																										
4	2016	Escalade	Chassis	Parking Brake Control Module																																																										
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2016	Escalade	Chassis	Power Steering Control Module																																																										
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2016	Escalade	Chassis	Suspension Control Module																																																										
4	2016	Escalade	Body	Body Control Module																																																										
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2016	Escalade	Body	Passenger Presence Module																																																										
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2016	Escalade	Body	Instrument Cluster																																																										
4	2016	Escalade	Body	Radio/HVAC Control																																																										
4	2016	Escalade	Body	Active Safety Control Module																																																										
4	2016	Escalade	Body	Video Processing Control Module																																																										
4	2016	Escalade	Body	Radio																																																										
4	2016	Escalade	Body	Amplifier																																																										
4	2016	Escalade	Body	Media Disc Player																																																										
4	2016	Escalade	Body	Human Machine Interface Control Module																																																										
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																																										
4	2016	Escalade	Body	HVAC Control Module																																																										
4	2016	Escalade	Body	Liftgate Control Module																																																										
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																										
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																										
4	2016	Escalade	Body	Keyless Entry Control Module																																																										
4	2016	Escalade	Body	Assist Step Control Module																																																										
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																										
4	2016	Escalade	Body	Parking Assist Control Module																																																										
4	2016	Escalade	Body	Frontview Camera Module																																																										
4	2016	Escalade	Body	Steering Column Lock Control Module																																																										
4	2016	Escalade	Body	Long Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																											
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																												
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																																												
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																												
4	2016	Escalade ESV	Chassis	Suspension Control Module																																																												
4	2016	Escalade ESV	Body	Body Control Module																																																												
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
4	2016	Escalade ESV	Body	Passenger Presence Module																																																												
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																												
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																												
4	2016	Escalade ESV	Body	Instrument Cluster																																																												
4	2016	Escalade ESV	Body	Radio Control																																																												
4	2016	Escalade ESV	Body	HVAC Control																																																												
4	2016	Escalade ESV	Body	Active Safety Control Module																																																												
4	2016	Escalade ESV	Body	Video Processing Control Module																																																												
4	2016	Escalade ESV	Body	Radio																																																												
4	2016	Escalade ESV	Body	Amplifier																																																												
4	2016	Escalade ESV	Body	Media Disc Player																																																												
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																												
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																												
4	2016	Escalade ESV	Body	HVAC Control Module																																																												
4	2016	Escalade ESV	Body	Liftgate Control Module																																																												
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																												
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																												
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																												
4	2016	Escalade ESV	Body	Assist Step Control Module																																																												
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																												
4	2016	Escalade ESV	Body	Parking Assist Control Module																																																												
4	2016	Escalade ESV	Body	Frontview Camera Module																																																												
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																												
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																												
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																												
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																												
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																												
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																												
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																												
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																												
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																												
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																												
ALL	2004	Hearse	Chassis	DRP/ABS/TCS																																																												
ALL	2004	Hearse	Chassis	Magna Steer																																																												
ALL	2004	Hearse	Chassis	Rear Integration Module																																																												
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																												
ALL	2004	Hearse	Body	Amplifier (Delco)																																																												
ALL	2004	Hearse	Body	Dash Integration Module																																																												
ALL	2004	Hearse	Body	Driver Door Switch																																																												
ALL	2004	Hearse	Body	Driver Door Module																																																												
ALL	2004	Hearse	Body	Passenger Door Module																																																												
ALL	2004	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2004	Hearse	Body	Instrument Panel Module																																																												
ALL	2004	Hearse	Body	Personalization																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
ALL	2004	Hearse	Body	Radio																																																										
ALL	2004	Hearse	Body	Rear Integration Module																																																										
ALL	2004	Hearse	Body	Remote Function Actuation																																																										
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																																										
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																										
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																										
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																										
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																										
ALL	2004	Limousine	Chassis	DRP/ABS/TCS																																																										
ALL	2004	Limousine	Chassis	Magna Steer																																																										
ALL	2004	Limousine	Chassis	Rear Integration Module																																																										
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																										
ALL	2004	Limousine	Body	Amplifier (Delco)																																																										
ALL	2004	Limousine	Body	Dash Integration Module																																																										
ALL	2004	Limousine	Body	Driver Door Switch																																																										
ALL	2004	Limousine	Body	Driver Door Module																																																										
ALL	2004	Limousine	Body	Passenger Door Module																																																										
ALL	2004	Limousine	Body	Left Mid Door Module																																																										
ALL	2004	Limousine	Body	Left Rear Door Module																																																										
ALL	2004	Limousine	Body	Right Mid Door Module																																																										
ALL	2004	Limousine	Body	Right Rear Door Module																																																										
ALL	2004	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2004	Limousine	Body	Instrument Panel Module																																																										
ALL	2004	Limousine	Body	Memory Seat Module																																																										
ALL	2004	Limousine	Body	Navigation Radio																																																										
ALL	2004	Limousine	Body	Personalization																																																										
ALL	2004	Limousine	Body	Radio																																																										
ALL	2004	Limousine	Body	Rear Climate Control Panel																																																										
ALL	2004	Limousine	Body	Rear Integration Module																																																										
ALL	2004	Limousine	Body	Remote Function Actuation																																																										
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																																										
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																										
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																										
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																										
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																										
ALL	2005	Hearse	Chassis	DRP/ABS/TCS																																																										
ALL	2005	Hearse	Chassis	Magna Steer																																																										
ALL	2005	Hearse	Chassis	Rear Integration Module																																																										
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																										
ALL	2005	Hearse	Body	Amplifier (Delco)																																																										
ALL	2005	Hearse	Body	Dash Integration Module																																																										
ALL	2005	Hearse	Body	Driver Door Switch																																																										
ALL	2005	Hearse	Body	Driver Door Module																																																										
ALL	2005	Hearse	Body	Passenger Door Module																																																										
ALL	2005	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2005	Hearse	Body	Instrument Panel Module																																																										
ALL	2005	Hearse	Body	Personalization																																																										
ALL	2005	Hearse	Body	Radio																																																										
ALL	2005	Hearse	Body	Rear Integration Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
ALL	2005	Hearse	Body	Remote Function Actuation																																																										
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																																										
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																										
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																										
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																										
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																										
ALL	2005	Limousine	Chassis	DRP/ABS/TCS																																																										
ALL	2005	Limousine	Chassis	Magna Steer																																																										
ALL	2005	Limousine	Chassis	Rear Integration Module																																																										
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																										
ALL	2005	Limousine	Body	Amplifier (Delco)																																																										
ALL	2005	Limousine	Body	Dash Integration Module																																																										
ALL	2005	Limousine	Body	Driver Door Switch																																																										
ALL	2005	Limousine	Body	Driver Door Module																																																										
ALL	2005	Limousine	Body	Passenger Door Module																																																										
ALL	2005	Limousine	Body	Left Mid Door Module																																																										
ALL	2005	Limousine	Body	Left Rear Door Module																																																										
ALL	2005	Limousine	Body	Right Mid Door Module																																																										
ALL	2005	Limousine	Body	Right Rear Door Module																																																										
ALL	2005	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2005	Limousine	Body	Instrument Panel Module																																																										
ALL	2005	Limousine	Body	Memory Seat Module																																																										
ALL	2005	Limousine	Body	Navigation Radio																																																										
ALL	2005	Limousine	Body	Personalization																																																										
ALL	2005	Limousine	Body	Radio																																																										
ALL	2005	Limousine	Body	Rear Climate Control Panel																																																										
ALL	2005	Limousine	Body	Rear Integration Module																																																										
ALL	2005	Limousine	Body	Remote Function Actuation																																																										
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																																										
ALL	2006	Hearse	Powertrain	Engine Control Module																																																										
ALL	2006	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2006	Hearse	Body	Amplifier (Bose)																																																										
ALL	2006	Hearse	Body	Body Control Module																																																										
ALL	2006	Hearse	Body	Digital Radio Receiver																																																										
ALL	2006	Hearse	Body	Driver Door Switch																																																										
ALL	2006	Hearse	Body	Driver Position Module																																																										
ALL	2006	Hearse	Body	HVAC Control Module																																																										
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2006	Hearse	Body	Passenger Door Switch																																																										
ALL	2006	Hearse	Body	Passenger Presence System																																																										
ALL	2006	Hearse	Body	Radio																																																										
ALL	2006	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	Hearse	Body	Theft Deterrent Module																																																										
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
ALL	2006	Limousine	Powertrain	Engine Control Module																																																										
ALL	2006	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2006	Limousine	Body	Amplifier (Bose)																																																										
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2006	Limousine	Body	Body Control Module																																																										
ALL	2006	Limousine	Body	Digital Radio Receiver																																																										
ALL	2006	Limousine	Body	Driver Door Switch																																																										
ALL	2006	Limousine	Body	Driver Position Module																																																										
ALL	2006	Limousine	Body	HVAC Control Module																																																										
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2006	Limousine	Body	Passenger Door Switch																																																										
ALL	2006	Limousine	Body	Passenger Presence System																																																										
ALL	2006	Limousine	Body	Radio																																																										
ALL	2006	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	Limousine	Body	Theft Deterrent Module																																																										
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																																										
ALL	2007	Hearse	Powertrain	Engine Control Module																																																										
ALL	2007	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Hearse	Body	Amplifier (Bose)																																																										
ALL	2007	Hearse	Body	Body Control Module																																																										
ALL	2007	Hearse	Body	Digital Radio Receiver																																																										
ALL	2007	Hearse	Body	Driver Door Switch																																																										
ALL	2007	Hearse	Body	Driver Position Module																																																										
ALL	2007	Hearse	Body	HVAC Control Module																																																										
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2007	Hearse	Body	Passenger Door Switch																																																										
ALL	2007	Hearse	Body	Passenger Presence System																																																										
ALL	2007	Hearse	Body	Radio																																																										
ALL	2007	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	Hearse	Body	Theft Deterrent Module																																																										
ALL	2007	Limousine	Powertrain	Engine Control Module																																																										
ALL	2007	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Limousine	Body	Amplifier (Bose)																																																										
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2007	Limousine	Body	Body Control Module																																																										
ALL	2007	Limousine	Body	Digital Radio Receiver																																																										
ALL	2007	Limousine	Body	Driver Door Switch																																																										
ALL	2007	Limousine	Body	Driver Position Module																																																										
ALL	2007	Limousine	Body	HVAC Control Module																																																										
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2007	Limousine	Body	Passenger Door Switch																																																												
ALL	2007	Limousine	Body	Passenger Presence System																																																												
ALL	2007	Limousine	Body	Radio																																																												
ALL	2007	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2007	Limousine	Body	Theft Deterrent Module																																																												
ALL	2008	Hearse	Powertrain	Engine Control Module																																																												
ALL	2008	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2008	Hearse	Body	Amplifier (Bose)																																																												
ALL	2008	Hearse	Body	Body Control Module																																																												
ALL	2008	Hearse	Body	Climate Control Seat Module																																																												
ALL	2008	Hearse	Body	Digital Radio Receiver																																																												
ALL	2008	Hearse	Body	Driver Door Switch																																																												
ALL	2008	Hearse	Body	Driver Position Module																																																												
ALL	2008	Hearse	Body	HVAC Control Module																																																												
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2008	Hearse	Body	Passenger Door Switch																																																												
ALL	2008	Hearse	Body	Passenger Presence System																																																												
ALL	2008	Hearse	Body	Radio																																																												
ALL	2008	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2008	Hearse	Body	Theft Deterrent Module																																																												
ALL	2008	Limousine	Powertrain	Engine Control Module																																																												
ALL	2008	Limousine	Powertrain	Transmission Control Module																																																												
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																												
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																																												
ALL	2008	Limousine	Body	Amplifier (Bose)																																																												
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																												
ALL	2008	Limousine	Body	Body Control Module																																																												
ALL	2008	Limousine	Body	Climate Control Seat Module																																																												
ALL	2008	Limousine	Body	Digital Radio Receiver																																																												
ALL	2008	Limousine	Body	Driver Door Switch																																																												
ALL	2008	Limousine	Body	Driver Position Module																																																												
ALL	2008	Limousine	Body	HVAC Control Module																																																												
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2008	Limousine	Body	Passenger Door Switch																																																												
ALL	2008	Limousine	Body	Passenger Presence System																																																												
ALL	2008	Limousine	Body	Radio																																																												
ALL	2008	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2008	Limousine	Body	Theft Deterrent Module																																																												
ALL	2009	Hearse	Powertrain	Engine Control Module																																																												
ALL	2009	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2009	Hearse	Body	Amplifier (Bose)																																																												
ALL	2009	Hearse	Body	Body Control Module																																																												
ALL	2009	Hearse	Body	Climate Control Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
ALL	2009	Hearse	Body	Digital Radio Receiver																																																											
ALL	2009	Hearse	Body	Driver Door Switch																																																												
ALL	2009	Hearse	Body	Driver Position Module																																																												
ALL	2009	Hearse	Body	HVAC Control Module																																																												
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2009	Hearse	Body	Passenger Door Switch																																																												
ALL	2009	Hearse	Body	Passenger Presence System																																																												
ALL	2009	Hearse	Body	Radio																																																												
ALL	2009	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2009	Hearse	Body	Theft Deterrent Module																																																												
ALL	2009	Limousine	Powertrain	Engine Control Module																																																												
ALL	2009	Limousine	Powertrain	Transmission Control Module																																																												
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																												
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																																												
ALL	2009	Limousine	Body	Amplifier (Bose)																																																												
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																												
ALL	2009	Limousine	Body	Body Control Module																																																												
ALL	2009	Limousine	Body	Climate Control Seat Module																																																												
ALL	2009	Limousine	Body	Digital Radio Receiver																																																												
ALL	2009	Limousine	Body	Driver Door Switch																																																												
ALL	2009	Limousine	Body	Driver Position Module																																																												
ALL	2009	Limousine	Body	HVAC Control Module																																																												
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2009	Limousine	Body	Passenger Door Switch																																																												
ALL	2009	Limousine	Body	Passenger Presence System																																																												
ALL	2009	Limousine	Body	Radio																																																												
ALL	2009	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2009	Limousine	Body	Theft Deterrent Module																																																												
ALL	2010	Hearse	Powertrain	Engine Control Module																																																												
ALL	2010	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2010	Hearse	Body	Amplifier (Bose)																																																												
ALL	2010	Hearse	Body	Body Control Module																																																												
ALL	2010	Hearse	Body	Climate Control Seat Module																																																												
ALL	2010	Hearse	Body	Digital Radio Receiver																																																												
ALL	2010	Hearse	Body	Driver Door Switch																																																												
ALL	2010	Hearse	Body	Driver Position Module																																																												
ALL	2010	Hearse	Body	HVAC Control Module																																																												
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2010	Hearse	Body	Passenger Door Switch																																																												
ALL	2010	Hearse	Body	Passenger Presence System																																																												
ALL	2010	Hearse	Body	Radio																																																												
ALL	2010	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2010	Hearse	Body	Theft Deterrent Module																																																												
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																																												
ALL	2010	Limousine	Powertrain	Engine Control Module																																																												
ALL	2010	Limousine	Powertrain	Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																											
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																																											
ALL	2010	Limousine	Body	Amplifier (Bose)																																																											
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																											
ALL	2010	Limousine	Body	Body Control Module																																																											
ALL	2010	Limousine	Body	Climate Control Seat Module																																																											
ALL	2010	Limousine	Body	Digital Radio Receiver																																																											
ALL	2010	Limousine	Body	Driver Door Switch																																																											
ALL	2010	Limousine	Body	Driver Position Module																																																											
ALL	2010	Limousine	Body	HVAC Control Module																																																											
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2010	Limousine	Body	Passenger Door Switch																																																											
ALL	2010	Limousine	Body	Passenger Presence System																																																											
ALL	2010	Limousine	Body	Radio																																																											
ALL	2010	Limousine	Body	Rear Heated Seat Module																																																											
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																																											
ALL	2010	Limousine	Body	Theft Deterrent Module																																																											
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																																											
ALL	2011	Hearse	Powertrain	Engine Control Module																																																											
ALL	2011	Hearse	Powertrain	Transmission Control Module																																																											
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																											
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																																											
ALL	2011	Hearse	Body	Amplifier (Bose)																																																											
ALL	2011	Hearse	Body	Body Control Module																																																											
ALL	2011	Hearse	Body	Climate Control Seat Module																																																											
ALL	2011	Hearse	Body	Digital Radio Receiver																																																											
ALL	2011	Hearse	Body	Driver Door Switch																																																											
ALL	2011	Hearse	Body	Driver Position Module																																																											
ALL	2011	Hearse	Body	HVAC Control Module																																																											
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																											
ALL	2011	Hearse	Body	Passenger Door Switch																																																											
ALL	2011	Hearse	Body	Passenger Presence System																																																											
ALL	2011	Hearse	Body	Radio																																																											
ALL	2011	Hearse	Body	Rear Heated Seat Module																																																											
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																																											
ALL	2011	Hearse	Body	Theft Deterrent Module																																																											
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																																											
ALL	2011	Limousine	Powertrain	Engine Control Module																																																											
ALL	2011	Limousine	Powertrain	Transmission Control Module																																																											
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																											
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																																											
ALL	2011	Limousine	Body	Amplifier (Bose)																																																											
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																											
ALL	2011	Limousine	Body	Body Control Module																																																											
ALL	2011	Limousine	Body	Climate Control Seat Module																																																											
ALL	2011	Limousine	Body	Digital Radio Receiver																																																											
ALL	2011	Limousine	Body	Driver Door Switch																																																											
ALL	2011	Limousine	Body	Driver Position Module																																																											
ALL	2011	Limousine	Body	HVAC Control Module																																																											
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2011	Limousine	Body	Passenger Door Switch																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
ALL	2011	Limousine	Body	Passenger Presence System																																																											
ALL	2011	Limousine	Body	Radio																																																												
ALL	2011	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2011	Limousine	Body	Theft Deterrent Module																																																												
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Instrument Panel Cluster																																																										
C	2004	ALL	Body	OnStar																																																										
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Base Radio																																																										
C	2004	ALL	Body	Uplevel Radio																																																										
C	2004	ALL	Body	Navigation Radio																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																										
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																										
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	ESC																																																									
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2005	ALL	Chassis	VSES																																																									
C	2005	ALL	Body	Amplifier (Bose)																																																										
C	2005	ALL	Body	Body Control Module																																																										
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																																										
C	2005	ALL	Body	Driver Seat Module																																																										
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2005	ALL	Body	Instrument Panel Cluster																																																										
C	2005	ALL	Body	Passenger Door Module																																																										
C	2005	ALL	Body	Passenger Presence System																																																										
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio																																																										
C	2005	ALL	Body	Rear Aux. Climate Module																																																										
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																																										
C	2005	ALL	Body	Remote Function Actuation																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																									
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																										
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	ALL	Chassis	Electronic Brake Control Module																																																										
C	2007	ALL	Chassis	Electronic Suspension Control																																																										
C	2007	ALL	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2007	ALL	Body	Assist Step Controller																																																								
C	2007	ALL	Body	Body Control Module																																																								
C	2007	ALL	Body	Body Control Module (aux.)																																																								
C	2007	ALL	Body	Digital Radio Receiver																																																								
C	2007	ALL	Body	Driver Door Switch																																																								
C	2007	ALL	Body	HVAC Control Module																																																								
C	2007	ALL	Body	Inside Rear View Mirror Module																																																								
C	2007	ALL	Body	Instrument Panel Cluster																																																								
C	2007	ALL	Body	Lift Gate Module																																																								
C	2007	ALL	Body	Memory Seat Module																																																								
C	2007	ALL	Body	Park Assist Module																																																								
C	2007	ALL	Body	Passenger Door Switch																																																								
C	2007	ALL	Body	Passenger Presence System																																																								
C	2007	ALL	Body	Radio																																																								
C	2007	ALL	Body	Rear Heated Seat Module																																																								
C	2007	ALL	Body	Rear HVAC/RSA																																																								
C	2007	ALL	Body	Rollover Sensor																																																								
C	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2007	ALL	Body	Theft Deterrent Module																																																								
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																								
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
C	2008	ALL	Chassis	Electronic Brake Control Module																																																								
C	2008	ALL	Chassis	Electronic Suspension Control																																																								
C	2008	ALL	Chassis	Trailer Brake Control Module																																																								
C	2008	ALL	Body	Amplifier (Bose)																																																								
C	2008	ALL	Body	Assist Step Controller																																																								
C	2008	ALL	Body	Body Control Module																																																								
C	2008	ALL	Body	Body Control Module (aux.)																																																								
C	2008	ALL	Body	Digital Radio Receiver																																																								
C	2008	ALL	Body	Driver Door Switch																																																								
C	2008	ALL	Body	HVAC Control Module																																																								
C	2008	ALL	Body	Inside Rear View Mirror Module																																																								
C	2008	ALL	Body	Instrument Panel Cluster																																																								
C	2008	ALL	Body	Lift Gate Module																																																								
C	2008	ALL	Body	Memory Seat Module																																																								
C	2008	ALL	Body	Park Assist Module																																																								
C	2008	ALL	Body	Passenger Door Switch																																																								
C	2008	ALL	Body	Passenger Presence System																																																								
C	2008	ALL	Body	Radio																																																								
C	2008	ALL	Body	Rear Heated Seat Module																																																								
C	2008	ALL	Body	Rear HVAC/RSA																																																								
C	2008	ALL	Body	Rollover Sensor																																																								
C	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2008	ALL	Body	Theft Deterrent Module																																																								
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2009	ALL	Chassis	Electronic Brake Control Module																																																								
C	2009	ALL	Chassis	Electronic Suspension Control																																																								
C	2009	ALL	Chassis	Trailer Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2009	ALL	Body	Amplifier (Bose)																																																									
C	2009	ALL	Body	Assist Step Controller																																																									
C	2009	ALL	Body	Body Control Module																																																									
C	2009	ALL	Body	Body Control Module (aux.)																																																									
C	2009	ALL	Body	Digital Radio Receiver																																																									
C	2009	ALL	Body	Driver Door Switch																																																									
C	2009	ALL	Body	HVAC Control Module																																																									
C	2009	ALL	Body	Inside Rear View Mirror Module																																																										
C	2009	ALL	Body	Instrument Panel Cluster																																																										
C	2009	ALL	Body	Left Side Object Detection Module																																																										
C	2009	ALL	Body	Lift Gate Module																																																										
C	2009	ALL	Body	Memory Seat Module																																																										
C	2009	ALL	Body	Park Assist Module																																																										
C	2009	ALL	Body	Passenger Door Switch																																																										
C	2009	ALL	Body	Passenger Presence System																																																										
C	2009	ALL	Body	Radio																																																										
C	2009	ALL	Body	Rear Heated Seat Module																																																										
C	2009	ALL	Body	Rear HVAC/RSA																																																										
C	2009	ALL	Body	Right Side Object Detection Module																																																										
C	2009	ALL	Body	Rollover Sensor																																																										
C	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2009	ALL	Body	Theft Deterrent Module																																																										
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	ALL	Chassis	Electronic Brake Control Module																																																										
C	2010	ALL	Chassis	Electronic Suspension Control																																																										
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	ALL	Body	Amplifier (Bose)																																																										
C	2010	ALL	Body	Assist Step Controller																																																										
C	2010	ALL	Body	Body Control Module																																																										
C	2010	ALL	Body	Body Control Module (aux.)																																																										
C	2010	ALL	Body	Digital Radio Receiver																																																										
C	2010	ALL	Body	Driver Door Switch																																																										
C	2010	ALL	Body	HVAC Control Module																																																										
C	2010	ALL	Body	Inside Rear View Mirror Module																																																										
C	2010	ALL	Body	Instrument Panel Cluster																																																										
C	2010	ALL	Body	Left Side Object Detection Module																																																										
C	2010	ALL	Body	Lift Gate Module																																																										
C	2010	ALL	Body	Memory Seat Module																																																										
C	2010	ALL	Body	Park Assist Module																																																										
C	2010	ALL	Body	Passenger Door Switch																																																										
C	2010	ALL	Body	Passenger Presence System																																																										
C	2010	ALL	Body	Radio																																																										
C	2010	ALL	Body	Rear Heated Seat Module																																																										
C	2010	ALL	Body	Rear HVAC/RSA																																																										
C	2010	ALL	Body	Right Side Object Detection Module																																																										
C	2010	ALL	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2010	ALL	Body	Theft Deterrent Module																																																									
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																																										
E	2004	ALL	Chassis	Electronic Suspension Control																																																										
E	2004	ALL	Chassis	Tire Pressure Monitor																																																										
E	2004	ALL	Chassis	VES																																																										
E	2004	ALL	Body	Amplifier (Bose)																																																										
E	2004	ALL	Body	Amplifier (Delco)																																																										
E	2004	ALL	Body	Climate Control Panel																																																										
E	2004	ALL	Body	Dash Integration Module																																																										
E	2004	ALL	Body	Disc Player and Video Display																																																										
E	2004	ALL	Body	Driver Door Switch																																																										
E	2004	ALL	Body	Driver Door Module																																																										
E	2004	ALL	Body	Passenger Door Module																																																										
E	2004	ALL	Body	Left Rear Door Module																																																										
E	2004	ALL	Body	Right Rear Door Module																																																										
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2004	ALL	Body	Instrument Panel Cluster																																																										
E	2004	ALL	Body	Memory Seat Module																																																										
E	2004	ALL	Body	OnStar																																																										
E	2004	ALL	Body	Personalization																																																										
E	2004	ALL	Body	Base Radio																																																										
E	2004	ALL	Body	Navigation Radio																																																										
E	2004	ALL	Body	Rear Integration Module																																																										
E	2004	ALL	Body	Rear Seat Module																																																										
E	2004	ALL	Body	Remote Function Actuation																																																										
E	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2004	ALL	Body	TV Antenna Module																																																										
E	2004	ALL	Body	Vehicle Theft Deterrent																																																										
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																																										
E	2005	ALL	Chassis	Electronic Suspension Control																																																										
E	2005	ALL	Chassis	Tire Pressure Monitor																																																										
E	2005	ALL	Chassis	VES																																																										
E	2005	ALL	Body	Amplifier (Bose)																																																										
E	2005	ALL	Body	Amplifier (Delco)																																																										
E	2005	ALL	Body	Climate Control Panel																																																										
E	2005	ALL	Body	Dash Integration Module																																																										
E	2005	ALL	Body	Disc Player and Video Display																																																										
E	2005	ALL	Body	Driver Door Switch																																																										
E	2005	ALL	Body	Driver Door Module																																																										
E	2005	ALL	Body	Passenger Door Module																																																										
E	2005	ALL	Body	Left Rear Door Module																																																										
E	2005	ALL	Body	Right Rear Door Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2005	ALL	Body	Instrument Panel Cluster																																																										
E	2005	ALL	Body	Memory Seat Module																																																										
E	2005	ALL	Body	Personalization																																																										
E	2005	ALL	Body	Base Radio																																																										
E	2005	ALL	Body	Navigation Radio																																																										
E	2005	ALL	Body	Rear Integration Module																																																										
E	2005	ALL	Body	Rear Seat Module																																																										
E	2005	ALL	Body	Remote Function Actuation																																																										
E	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2005	ALL	Body	TV Antenna Module																																																										
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
E	2005	ALL	Body	Vehicle Theft Deterrent																																																										
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																										
E	2006	ALL	Chassis	Electronic Suspension Control																																																										
E	2006	ALL	Chassis	Tire Pressure Monitor																																																										
E	2006	ALL	Chassis	VES																																																										
E	2006	ALL	Body	Amplifier (Bose)																																																										
E	2006	ALL	Body	Amplifier (Delco)																																																										
E	2006	ALL	Body	Climate Control Panel																																																										
E	2006	ALL	Body	Dash Integration Module																																																										
E	2006	ALL	Body	Disc Player and Video Display																																																										
E	2006	ALL	Body	Driver Door Switch																																																										
E	2006	ALL	Body	Driver Door Module																																																										
E	2006	ALL	Body	Passenger Door Module																																																										
E	2006	ALL	Body	Left Rear Door Module																																																										
E	2006	ALL	Body	Right Rear Door Module																																																										
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2006	ALL	Body	Instrument Panel Cluster																																																										
E	2006	ALL	Body	Lift Gate Module																																																										
E	2006	ALL	Body	Memory Seat Module																																																										
E	2006	ALL	Body	Personalization																																																										
E	2006	ALL	Body	Base Radio																																																										
E	2006	ALL	Body	Navigation Radio																																																										
E	2006	ALL	Body	Rear Integration Module																																																										
E	2006	ALL	Body	Rear Seat Module																																																										
E	2006	ALL	Body	Remote Function Actuation																																																										
E	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
E	2006	ALL	Body	Vehicle Theft Deterrent																																																										
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2007	ALL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
E	2007	ALL	Chassis	Electronic Suspension Control																																																									
E	2007	ALL	Body	Amplifier (Bose)																																																										
E	2007	ALL	Body	Body Control Module																																																										
E	2007	ALL	Body	Body Control Module (aux.)																																																										
E	2007	ALL	Body	Digital Radio Receiver																																																										
E	2007	ALL	Body	Driver Door Switch																																																										
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2007	ALL	Body	HVAC Control Module																																																										
E	2007	ALL	Body	Instrument Panel Cluster																																																										
E	2007	ALL	Body	Lift Gate Module																																																										
E	2007	ALL	Body	Memory Seat Module																																																										
E	2007	ALL	Body	Park Assist Module																																																										
E	2007	ALL	Body	Passenger Door Switch																																																										
E	2007	ALL	Body	Passenger Presence System																																																										
E	2007	ALL	Body	Radio																																																										
E	2007	ALL	Body	Rear HVAC/RSA																																																										
E	2007	ALL	Body	Rear Seat Module																																																										
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																										
E	2007	ALL	Body	Rollover Sensor																																																										
E	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2007	ALL	Body	Theft Deterrent Module																																																										
E	2007	ALL	Body	TV Antenna Module																																																										
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2008	ALL	Chassis	Electronic Brake Control Module																																																										
E	2008	ALL	Chassis	Electronic Suspension Control																																																										
E	2008	ALL	Body	Amplifier (Bose)																																																										
E	2008	ALL	Body	Body Control Module																																																										
E	2008	ALL	Body	Body Control Module (aux.)																																																										
E	2008	ALL	Body	Digital Radio Receiver																																																										
E	2008	ALL	Body	Driver Door Switch																																																										
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2008	ALL	Body	HVAC Control Module																																																										
E	2008	ALL	Body	Instrument Panel Cluster																																																										
E	2008	ALL	Body	Lift Gate Module																																																										
E	2008	ALL	Body	Memory Seat Module																																																										
E	2008	ALL	Body	Park Assist Module																																																										
E	2008	ALL	Body	Passenger Door Switch																																																										
E	2008	ALL	Body	Passenger Presence System																																																										
E	2008	ALL	Body	Radio																																																										
E	2008	ALL	Body	Rear HVAC/RSA																																																										
E	2008	ALL	Body	Rear Seat Module																																																										
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
E	2008	ALL	Body	Rollover Sensor																																																										
E	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2008	ALL	Body	Theft Deterrent Module																																																										
E	2008	ALL	Body	TV Antenna Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																									
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																									
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																									
E	2009	ALL	Chassis	Electronic Brake Control Module																																																									
E	2009	ALL	Chassis	Electronic Suspension Control																																																									
E	2009	ALL	Body	Amplifier (Bose)																																																									
E	2009	ALL	Body	Body Control Module																																																									
E	2009	ALL	Body	Body Control Module (aux.)																																																									
E	2009	ALL	Body	Digital Radio Receiver																																																									
E	2009	ALL	Body	Driver Door Switch																																																									
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																									
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																									
E	2009	ALL	Body	HVAC Control Module																																																									
E	2009	ALL	Body	Instrument Panel Cluster																																																									
E	2009	ALL	Body	Lift Gate Module																																																									
E	2009	ALL	Body	Memory Seat Module																																																									
E	2009	ALL	Body	Park Assist Module																																																									
E	2009	ALL	Body	Passenger Door Switch																																																									
E	2009	ALL	Body	Passenger Presence System																																																									
E	2009	ALL	Body	Radio																																																									
E	2009	ALL	Body	Rear HVAC/RSA																																																									
E	2009	ALL	Body	Rear Seat Module																																																									
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																									
E	2009	ALL	Body	Rollover Sensor																																																									
E	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
E	2009	ALL	Body	Theft Deterrent Module																																																									
E	2009	ALL	Body	TV Antenna Module																																																									
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																									
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2004	ALL	Chassis	ESC																																																								
K	2004	ALL	Chassis	Rear Wheel Steering																																																									
K	2004	ALL	Chassis	Tire Pressure Monitor																																																									
K	2004	ALL	Chassis	VSES																																																									
K	2004	ALL	Body	Amplifier (Bose)																																																									
K	2004	ALL	Body	Body Control Module																																																									
K	2004	ALL	Body	CD Changer																																																									
K	2004	ALL	Body	Chime																																																									
K	2004	ALL	Body	Driver Door Module																																																									
K	2004	ALL	Body	Driver Seat Module																																																									
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																									
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2004	ALL	Body	Instrument Panel Cluster																																																									
K	2004	ALL	Body	OnStar																																																									
K	2004	ALL	Body	Passenger Door Module																																																									
K	2004	ALL	Body	Passenger Presence System																																																									
K	2004	ALL	Body	Base Radio																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2004	ALL	Body	Uplevel Radio																																																									
K	2004	ALL	Body	Navigation Radio																																																									
K	2004	ALL	Body	Rear Aux. Climate Module																																																										
K	2004	ALL	Body	Rear HVAC																																																										
K	2004	ALL	Body	Rear Seat Audio																																																										
K	2004	ALL	Body	Rear Seat Entertainment																																																										
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	ESC																																																									
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	VSES																																																									
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Remote Function Actuation																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2006	ALL	Chassis	ESC																																																									
K	2006	ALL	Chassis	Tire Pressure Monitor																																																										
K	2006	ALL	Chassis	VSES																																																									
K	2006	ALL	Body	Amplifier (Bose)																																																										
K	2006	ALL	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2006	ALL	Body	CD Changer																																																									
K	2006	ALL	Body	Chime																																																									
K	2006	ALL	Body	Disc Player and Video Display																																																									
K	2006	ALL	Body	Driver Door Module																																																									
K	2006	ALL	Body	Driver Seat Module																																																									
K	2006	ALL	Body	Generator Battery Control Module																																																									
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																									
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2006	ALL	Body	Instrument Panel Cluster																																																									
K	2006	ALL	Body	Passenger Door Module																																																									
K	2006	ALL	Body	Passenger Presence System																																																									
K	2006	ALL	Body	Base Radio																																																									
K	2006	ALL	Body	Uplevel Radio																																																									
K	2006	ALL	Body	Navigation Radio																																																									
K	2006	ALL	Body	Rear Aux. Climate Module																																																									
K	2006	ALL	Body	Rear HVAC																																																									
K	2006	ALL	Body	Rear Seat Audio																																																									
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2007	ALL	Chassis	Electronic Brake Control Module																																																									
K	2007	ALL	Chassis	Electronic Suspension Control																																																									
K	2007	ALL	Body	Amplifier (Bose)																																																									
K	2007	ALL	Body	Assist Step Controller																																																									
K	2007	ALL	Body	Body Control Module																																																									
K	2007	ALL	Body	Body Control Module (aux.)																																																									
K	2007	ALL	Body	Digital Radio Receiver																																																									
K	2007	ALL	Body	Driver Door Switch																																																									
K	2007	ALL	Body	HVAC Control Module																																																									
K	2007	ALL	Body	Inside Rear View Mirror Module																																																									
K	2007	ALL	Body	Instrument Panel Cluster																																																									
K	2007	ALL	Body	Lift Gate Module																																																									
K	2007	ALL	Body	Memory Seat Module																																																									
K	2007	ALL	Body	Park Assist Module																																																									
K	2007	ALL	Body	Passenger Door Switch																																																									
K	2007	ALL	Body	Passenger Presence System																																																									
K	2007	ALL	Body	Radio																																																									
K	2007	ALL	Body	Rear Heated Seat Module																																																									
K	2007	ALL	Body	Rear HVAC/RSA																																																									
K	2007	ALL	Body	Rollover Sensor																																																									
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2007	ALL	Body	Theft Deterrent Module																																																									
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2008	ALL	Chassis	Electronic Brake Control Module																																																									
K	2008	ALL	Chassis	Electronic Suspension Control																																																									
K	2008	ALL	Chassis	Trailer Brake Control Module																																																									
K	2008	ALL	Body	Amplifier (Bose)																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2008	ALL	Body	Assist Step Controller																																																									
K	2008	ALL	Body	Body Control Module																																																									
K	2008	ALL	Body	Body Control Module (aux.)																																																									
K	2008	ALL	Body	Digital Radio Receiver																																																									
K	2008	ALL	Body	Driver Door Switch																																																									
K	2008	ALL	Body	HVAC Control Module																																																									
K	2008	ALL	Body	Inside Rear View Mirror Module																																																									
K	2008	ALL	Body	Instrument Panel Cluster																																																									
K	2008	ALL	Body	Lift Gate Module																																																									
K	2008	ALL	Body	Memory Seat Module																																																									
K	2008	ALL	Body	Park Assist Module																																																									
K	2008	ALL	Body	Passenger Door Switch																																																									
K	2008	ALL	Body	Passenger Presence System																																																									
K	2008	ALL	Body	Radio																																																									
K	2008	ALL	Body	Rear Heated Seat Module																																																									
K	2008	ALL	Body	Rear HVAC/RSA																																																									
K	2008	ALL	Body	Rollover Sensor																																																									
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2008	ALL	Body	Theft Deterrent Module																																																									
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
K	2009	ALL	Chassis	Electronic Brake Control Module																																																									
K	2009	ALL	Chassis	Electronic Suspension Control																																																									
K	2009	ALL	Chassis	Trailer Brake Control Module																																																									
K	2009	ALL	Body	Amplifier (Bose)																																																									
K	2009	ALL	Body	Assist Step Controller																																																									
K	2009	ALL	Body	Body Control Module																																																									
K	2009	ALL	Body	Body Control Module (aux.)																																																									
K	2009	ALL	Body	Digital Radio Receiver																																																									
K	2009	ALL	Body	Driver Door Switch																																																									
K	2009	ALL	Body	HVAC Control Module																																																									
K	2009	ALL	Body	Inside Rear View Mirror Module																																																									
K	2009	ALL	Body	Instrument Panel Cluster																																																									
K	2009	ALL	Body	Left Side Object Detection Module																																																									
K	2009	ALL	Body	Lift Gate Module																																																									
K	2009	ALL	Body	Memory Seat Module																																																									
K	2009	ALL	Body	Park Assist Module																																																									
K	2009	ALL	Body	Passenger Door Switch																																																									
K	2009	ALL	Body	Passenger Presence System																																																									
K	2009	ALL	Body	Radio																																																									
K	2009	ALL	Body	Rear Heated Seat Module																																																									
K	2009	ALL	Body	Rear HVAC/RSA																																																									
K	2009	ALL	Body	Right Side Object Detection Module																																																									
K	2009	ALL	Body	Rollover Sensor																																																									
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2009	ALL	Body	Theft Deterrent Module																																																									
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	ALL	Chassis	Electronic Brake Control Module																																																											
K	2010	ALL	Chassis	Electronic Suspension Control																																																											
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	ALL	Body	Amplifier (Bose)																																																											
K	2010	ALL	Body	Assist Step Controller																																																											
K	2010	ALL	Body	Body Control Module																																																											
K	2010	ALL	Body	Body Control Module (aux.)																																																											
K	2010	ALL	Body	Digital Radio Receiver																																																											
K	2010	ALL	Body	Driver Door Switch																																																											
K	2010	ALL	Body	HVAC Control Module																																																											
K	2010	ALL	Body	Inside Rear View Mirror Module																																																											
K	2010	ALL	Body	Instrument Panel Cluster																																																											
K	2010	ALL	Body	Left Side Object Detection Module																																																											
K	2010	ALL	Body	Lift Gate Module																																																											
K	2010	ALL	Body	Memory Seat Module																																																											
K	2010	ALL	Body	Park Assist Module																																																											
K	2010	ALL	Body	Passenger Door Switch																																																											
K	2010	ALL	Body	Passenger Presence System																																																											
K	2010	ALL	Body	Radio																																																											
K	2010	ALL	Body	Rear Heated Seat Module																																																											
K	2010	ALL	Body	Rear HVAC/RSA																																																											
K	2010	ALL	Body	Right Side Object Detection Module																																																											
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2010	ALL	Body	Theft Deterrent Module																																																											
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																											
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																											
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																											
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																											
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																											
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																											
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2010	SRX	Chassis	Electronic Brake Control Module																																																											
N	2010	SRX	Chassis	Parking Brake Control Module																																																											
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2010	SRX	Chassis	Suspension Control Module																																																											
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2010	SRX	Body	Passenger Presence Module																																																											
N	2010	SRX	Body	Instrument Cluster																																																											
N	2010	SRX	Body	Headlamp Control Module																																																											
N	2010	SRX	Body	Trailer Interface Control Module																																																											
N	2010	SRX	Body	Radio																																																											
N	2010	SRX	Body	Rear Audio Control Module																																																											
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																											
N	2010	SRX	Body	Multimedia Player Interface Module																																																											
N	2010	SRX	Body	Mobile Telephone Control Module																																																											
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2010	SRX	Body	Liftgate Control Module																																																										
N	2010	SRX	Body	Seat Memory Control Module																																																										
N	2010	SRX	Body	Front Seat Heating Control Module																																																										
N	2010	SRX	Body	Rear Seat Heating Control Module																																																										
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2010	SRX	Body	Parking Assist Control Module																																																										
N	2010	SRX	Body	Steering Column Lock Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2011	SRX	Chassis	Electronic Brake Control Module																																																										
N	2011	SRX	Chassis	Parking Brake Control Module																																																										
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2011	SRX	Chassis	Suspension Control Module																																																										
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2011	SRX	Body	Passenger Presence Module																																																										
N	2011	SRX	Body	Instrument Cluster																																																										
N	2011	SRX	Body	Headlamp Control Module																																																										
N	2011	SRX	Body	Trailer Interface Control Module																																																										
N	2011	SRX	Body	Radio																																																										
N	2011	SRX	Body	Rear Audio Control Module																																																										
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2011	SRX	Body	Multimedia Player Interface Module																																																										
N	2011	SRX	Body	Mobile Telephone Control Module																																																										
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2011	SRX	Body	Liftgate Control Module																																																										
N	2011	SRX	Body	Seat Memory Control Module																																																										
N	2011	SRX	Body	Front Seat Heating Control Module																																																										
N	2011	SRX	Body	Rear Seat Heating Control Module																																																										
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2011	SRX	Body	Parking Assist Control Module																																																										
N	2011	SRX	Body	Steering Column Lock Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																										
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2012	SRX	Chassis	Electronic Brake Control Module																																																										
N	2012	SRX	Chassis	Parking Brake Control Module																																																										
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2012	SRX	Chassis	Suspension Control Module																																																										
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2012	SRX	Body	Passenger Presence Module																																																										
N	2012	SRX	Body	Instrument Cluster																																																										
N	2012	SRX	Body	Headlamp Control Module																																																										
N	2012	SRX	Body	Trailer Interface Control Module																																																										
N	2012	SRX	Body	Radio																																																										
N	2012	SRX	Body	Rear Audio Control Module																																																										
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2012	SRX	Body	Multimedia Player Interface Module																																																										
N	2012	SRX	Body	Mobile Telephone Control Module																																																										
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2012	SRX	Body	Liftgate Control Module																																																										
N	2012	SRX	Body	Seat Memory Control Module																																																										
N	2012	SRX	Body	Front Seat Heating Control Module																																																										
N	2012	SRX	Body	Rear Seat Heating Control Module																																																										
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2012	SRX	Body	Parking Assist Control Module																																																										
N	2012	SRX	Body	Steering Column Lock Control Module																																																										
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2013	SRX	Chassis	Electronic Brake Control Module																																																										
N	2013	SRX	Chassis	Parking Brake Control Module																																																										
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2013	SRX	Chassis	Suspension Control Module																																																										
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2013	SRX	Body	Passenger Presence Module																																																										
N	2013	SRX	Body	Instrument Cluster																																																										
N	2013	SRX	Body	Radio/HVAC Control																																																										
N	2013	SRX	Body	Active Safety Control Module																																																										
N	2013	SRX	Body	Headlamp Control Module																																																										
N	2013	SRX	Body	Trailer Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
N	2013	SRX	Body	Radio																																																									
N	2013	SRX	Body	Amplifier																																																									
N	2013	SRX	Body	Media Disc Player																																																									
N	2013	SRX	Body	Human Machine Interface Control Module																																																									
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																																									
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																																									
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																									
N	2013	SRX	Body	Liftgate Control Module																																																									
N	2013	SRX	Body	Seat Memory Control Module																																																									
N	2013	SRX	Body	Rear Seat Heating Control Module																																																									
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																									
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
N	2013	SRX	Body	Right Side Object Detection Control Module																																																									
N	2013	SRX	Body	Left Side Object Detection Control Module																																																									
N	2013	SRX	Body	Parking Assist Control Module																																																									
N	2013	SRX	Body	Frontview Camera Module																																																									
N	2013	SRX	Body	Steering Column Lock Control Module																																																									
N	2013	SRX	Body	Long Range Radar Sensor Module																																																									
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																									
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																									
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																									
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2014	SRX	Chassis	Electronic Brake Control Module																																																									
N	2014	SRX	Chassis	Parking Brake Control Module																																																									
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2014	SRX	Chassis	Suspension Control Module																																																									
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2014	SRX	Body	Passenger Presence Module																																																									
N	2014	SRX	Body	Instrument Cluster																																																									
N	2014	SRX	Body	Radio/HVAC Control																																																									
N	2014	SRX	Body	Active Safety Control Module																																																									
N	2014	SRX	Body	Headlamp Control Module																																																									
N	2014	SRX	Body	Trailer Interface Control Module																																																									
N	2014	SRX	Body	Radio																																																									
N	2014	SRX	Body	Amplifier																																																									
N	2014	SRX	Body	Media Disc Player																																																									
N	2014	SRX	Body	Human Machine Interface Control Module																																																									
N	2014	SRX	Body	Navigation Control Module																																																									
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																									
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																																									
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																									
N	2014	SRX	Body	Liftgate Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2014	SRX	Body	Rear Seat Heating Control Module																																																											
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2014	SRX	Body	Right Side Object Detection Control Module																																																											
N	2014	SRX	Body	Left Side Object Detection Control Module																																																											
N	2014	SRX	Body	Parking Assist Control Module																																																											
N	2014	SRX	Body	Frontview Camera Module																																																											
N	2014	SRX	Body	Steering Column Lock Control Module																																																											
N	2014	SRX	Body	Long Range Radar Sensor Module																																																											
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																											
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2015	SRX	Chassis	Electronic Brake Control Module																																																											
N	2015	SRX	Chassis	Parking Brake Control Module																																																											
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2015	SRX	Chassis	Suspension Control Module																																																											
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2015	SRX	Body	Passenger Presence Module																																																											
N	2015	SRX	Body	Instrument Cluster																																																											
N	2015	SRX	Body	Radio/HVAC Control																																																											
N	2015	SRX	Body	Active Safety Control Module																																																											
N	2015	SRX	Body	Headlamp Control Module																																																											
N	2015	SRX	Body	Trailer Interface Control Module																																																											
N	2015	SRX	Body	Radio																																																											
N	2015	SRX	Body	Amplifier																																																											
N	2015	SRX	Body	Rear Audio Control Module																																																											
N	2015	SRX	Body	Media Disc Player																																																											
N	2015	SRX	Body	Human Machine Interface Control Module																																																											
N	2015	SRX	Body	Navigation Control Module																																																											
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																											
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
N	2015	SRX	Body	Liftgate Control Module																																																											
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																											
N	2015	SRX	Body	Rear Seat Heating Control Module																																																											
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2015	SRX	Body	Right Side Object Detection Control Module																																																											
N	2015	SRX	Body	Left Side Object Detection Control Module																																																											
N	2015	SRX	Body	Parking Assist Control Module																																																											
N	2015	SRX	Body	Frontview Camera Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
N	2015	SRX	Body	Steering Column Lock Control Module																																																										
N	2015	SRX	Body	Long Range Radar Sensor Module																																																											
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																											
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2016	SRX	Chassis	Electronic Brake Control Module																																																											
N	2016	SRX	Chassis	Parking Brake Control Module																																																											
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2016	SRX	Chassis	Suspension Control Module																																																											
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2016	SRX	Body	Passenger Presence Module																																																											
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																																											
N	2016	SRX	Body	Radio/HVAC Control																																																											
N	2016	SRX	Body	Active Safety Control Module																																																											
N	2016	SRX	Body	Headlamp Control Module																																																											
N	2016	SRX	Body	Trailer Interface Control Module																																																											
N	2016	SRX	Body	Radio																																																											
N	2016	SRX	Body	Amplifier																																																										
N	2016	SRX	Body	Rear Audio Control Module																																																											
N	2016	SRX	Body	Media Disc Player																																																											
N	2016	SRX	Body	Human Machine Interface Control Module																																																											
N	2016	SRX	Body	Navigation Control Module																																																											
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																											
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
N	2016	SRX	Body	Liftgate Control Module																																																											
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																											
N	2016	SRX	Body	Rear Seat Heating Control Module																																																											
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2016	SRX	Body	Right Side Object Detection Control Module																																																											
N	2016	SRX	Body	Left Side Object Detection Control Module																																																											
N	2016	SRX	Body	Parking Assist Control Module																																																											
N	2016	SRX	Body	Frontview Camera Module																																																											
N	2016	SRX	Body	Steering Column Lock Control Module																																																											
N	2016	SRX	Body	Long Range Radar Sensor Module																																																											
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																											
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
3	2011	ALL	Chassis	Electronic Brake Control Module																																																										
3	2011	ALL	Chassis	Electronic Suspension Control																																																										
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2011	ALL	Body	Amplifier (Bose)																																																										
3	2011	ALL	Body	Assist Step Controller																																																										
3	2011	ALL	Body	Body Control Module																																																										
3	2011	ALL	Body	Body Control Module (aux.)																																																										
3	2011	ALL	Body	Digital Radio Receiver																																																										
3	2011	ALL	Body	Driver Door Switch																																																										
3	2011	ALL	Body	HVAC Control Module																																																										
3	2011	ALL	Body	Inside Rear View Mirror Module																																																										
3	2011	ALL	Body	Instrument Panel Cluster																																																										
3	2011	ALL	Body	Left Side Object Detection Module																																																										
3	2011	ALL	Body	Lift Gate Module																																																										
3	2011	ALL	Body	Memory Seat Module																																																										
3	2011	ALL	Body	Park Assist Module																																																										
3	2011	ALL	Body	Passenger Door Switch																																																										
3	2011	ALL	Body	Passenger Presence System																																																										
3	2011	ALL	Body	Radio																																																										
3	2011	ALL	Body	Rear Heated Seat Module																																																										
3	2011	ALL	Body	Rear HVAC/RSA																																																										
3	2011	ALL	Body	Right Side Object Detection Module																																																										
3	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
3	2011	ALL	Body	Theft Deterrent Module																																																										
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
3	2012	ALL	Chassis	Electronic Brake Control Module																																																										
3	2012	ALL	Chassis	Electronic Suspension Control																																																										
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2012	ALL	Body	Amplifier (Bose)																																																										
3	2012	ALL	Body	Assist Step Controller																																																										
3	2012	ALL	Body	Body Control Module																																																										
3	2012	ALL	Body	Body Control Module (aux.)																																																										
3	2012	ALL	Body	Driver Door Switch																																																										
3	2012	ALL	Body	HVAC Control Module																																																										
3	2012	ALL	Body	Inside Rear View Mirror Module																																																										
3	2012	ALL	Body	Instrument Panel Cluster																																																										
3	2012	ALL	Body	Left Side Object Detection Module																																																										
3	2012	ALL	Body	Lift Gate Module																																																										
3	2012	ALL	Body	Memory Seat Module																																																										
3	2012	ALL	Body	Park Assist Module																																																										
3	2012	ALL	Body	Passenger Door Switch																																																										
3	2012	ALL	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
3	2012	ALL	Body	Radio																																																									
3	2012	ALL	Body	Rear Heated Seat Module																																																										
3	2012	ALL	Body	Rear HVAC/RSA																																																										
3	2012	ALL	Body	Right Side Object Detection Module																																																										
3	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
3	2012	ALL	Body	Theft Deterrent Module																																																										
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
3	2013	ALL	Chassis	Electronic Brake Control Module																																																										
3	2013	ALL	Chassis	Electronic Suspension Control																																																										
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																										
3	2013	ALL	Body	Amplifier (Bose)																																																										
3	2013	ALL	Body	Assist Step Controller																																																										
3	2013	ALL	Body	Body Control Module																																																										
3	2013	ALL	Body	Body Control Module (aux.)																																																										
3	2013	ALL	Body	Driver Door Switch																																																										
3	2013	ALL	Body	HVAC Control Module																																																										
3	2013	ALL	Body	Inside Rear View Mirror Module																																																										
3	2013	ALL	Body	Instrument Panel Cluster																																																										
3	2013	ALL	Body	Left Side Object Detection Module																																																										
3	2013	ALL	Body	Lift Gate Module																																																										
3	2013	ALL	Body	Memory Seat Module																																																										
3	2013	ALL	Body	Park Assist Module																																																										
3	2013	ALL	Body	Passenger Door Switch																																																										
3	2013	ALL	Body	Passenger Presence System																																																										
3	2013	ALL	Body	Radio																																																										
3	2013	ALL	Body	Rear Heated Seat Module																																																										
3	2013	ALL	Body	Rear HVAC/RSA																																																										
3	2013	ALL	Body	Right Side Object Detection Module																																																										
3	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
3	2013	ALL	Body	Theft Deterrent Module																																																										
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																										
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2014	Escalade	Chassis	Suspension Control Module																																																										
3	2014	Escalade	Body	Body Control Module																																																										
3	2014	Escalade	Body	Auxiliary Body Control Module																																																										
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2014	Escalade	Body	Passenger Presence Module																																																										
3	2014	Escalade	Body	Instrument Cluster																																																										
3	2014	Escalade	Body	Radio																																																										
3	2014	Escalade	Body	Amplifier																																																										
3	2014	Escalade	Body	Rear Audio Control Module																																																										
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																										
3	2014	Escalade	Body	Personal Audio Link Control Module																																																										
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																										
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
3	2014	Escalade	Body	HVAC Control Module																																																									
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																									
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																									
3	2014	Escalade	Body	Liftgate Control Module																																																									
3	2014	Escalade	Body	Seat Memory Control Module																																																									
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																									
3	2014	Escalade	Body	Assist Step Control Module																																																									
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																									
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																									
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																									
3	2014	Escalade	Body	Parking Assist Control Module																																																									
3	2014	Escalade	Body	Theft Deterrent Module																																																									
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																									
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																									
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																									
3	2014	Escalade ESV	Body	Body Control Module																																																									
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																									
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
3	2014	Escalade ESV	Body	Passenger Presence Module																																																									
3	2014	Escalade ESV	Body	Instrument Cluster																																																									
3	2014	Escalade ESV	Body	Radio																																																									
3	2014	Escalade ESV	Body	Amplifier																																																									
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																									
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																									
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																									
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																									
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																									
3	2014	Escalade ESV	Body	HVAC Control Module																																																									
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																									
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																									
3	2014	Escalade ESV	Body	Liftgate Control Module																																																									
3	2014	Escalade ESV	Body	Seat Memory Control Module																																																									
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																									
3	2014	Escalade ESV	Body	Assist Step Control Module																																																									
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																									
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																									
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																									
3	2014	Escalade ESV	Body	Parking Assist Control Module																																																									
3	2014	Escalade ESV	Body	Theft Deterrent Module																																																									
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																									
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																									
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																										
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																										
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																										
3	2015	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2015	Escalade	Chassis	Parking Brake Control Module																																																										
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2015	Escalade	Chassis	Power Steering Control Module																																																										
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2015	Escalade	Chassis	Suspension Control Module																																																										
3	2015	Escalade	Body	Body Control Module																																																										
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2015	Escalade	Body	Passenger Presence Module																																																										
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2015	Escalade	Body	Instrument Cluster																																																										
3	2015	Escalade	Body	Radio/HVAC Control																																																										
3	2015	Escalade	Body	Active Safety Control Module																																																										
3	2015	Escalade	Body	Video Processing Control Module																																																										
3	2015	Escalade	Body	Radio																																																										
3	2015	Escalade	Body	Amplifier																																																										
3	2015	Escalade	Body	Media Disc Player																																																										
3	2015	Escalade	Body	Human Machine Interface Control Module																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2015	Escalade	Body	HVAC Control Module																																																										
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																										
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																										
3	2015	Escalade	Body	Keyless Entry Control Module																																																										
3	2015	Escalade	Body	Assist Step Control Module																																																										
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																										
3	2015	Escalade	Body	Parking Assist Control Module																																																										
3	2015	Escalade	Body	Frontview Camera Module																																																										
3	2015	Escalade	Body	Steering Column Lock Control Module																																																										
3	2015	Escalade	Body	Battery Energy Control Module																																																										
3	2015	Escalade	Body	Long Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																										
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																																										
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2015	Escalade ESV	Body	Body Control Module																																																										
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2015	Escalade ESV	Body	Passenger Presence Module																																																										
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2015	Escalade ESV	Body	Instrument Cluster																																																										
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																										
3	2015	Escalade ESV	Body	Active Safety Control Module																																																										
3	2015	Escalade ESV	Body	Video Processing Control Module																																																										
3	2015	Escalade ESV	Body	Radio																																																										
3	2015	Escalade ESV	Body	Amplifier																																																										
3	2015	Escalade ESV	Body	Media Disc Player																																																										
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2015	Escalade ESV	Body	HVAC Control Module																																																										
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																										
3	2015	Escalade ESV	Body	Assist Step Control Module																																																										
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2015	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2015	Escalade ESV	Body	Frontview Camera Module																																																										
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																										
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2016	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2016	Escalade	Chassis	Parking Brake Control Module																																																										
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2016	Escalade	Chassis	Power Steering Control Module																																																										
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2016	Escalade	Chassis	Suspension Control Module																																																										
3	2016	Escalade	Body	Body Control Module																																																										
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
3	2016	Escalade	Body	Passenger Presence Module																																																										
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2016	Escalade	Body	Instrument Cluster																																																										
3	2016	Escalade	Body	Radio/HVAC Control																																																										
3	2016	Escalade	Body	Active Safety Control Module																																																										
3	2016	Escalade	Body	Video Processing Control Module																																																										
3	2016	Escalade	Body	Radio																																																										
3	2016	Escalade	Body	Amplifier																																																										
3	2016	Escalade	Body	Media Disc Player																																																										
3	2016	Escalade	Body	Human Machine Interface Control Module																																																										
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																																										
3	2016	Escalade	Body	HVAC Control Module																																																										
3	2016	Escalade	Body	Liftgate Control Module																																																										
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																										
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																										
3	2016	Escalade	Body	Keyless Entry Control Module																																																										
3	2016	Escalade	Body	Assist Step Control Module																																																										
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																										
3	2016	Escalade	Body	Parking Assist Control Module																																																										
3	2016	Escalade	Body	Frontview Camera Module																																																										
3	2016	Escalade	Body	Steering Column Lock Control Module																																																										
3	2016	Escalade	Body	Long Range Radar Sensor Module																																																										
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																										
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																																										
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2016	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2016	Escalade ESV	Body	Body Control Module																																																										
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2016	Escalade ESV	Body	Passenger Presence Module																																																										
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2016	Escalade ESV	Body	Instrument Cluster																																																										
3	2016	Escalade ESV	Body	Radio Control																																																										
3	2016	Escalade ESV	Body	HVAC Control																																																										
3	2016	Escalade ESV	Body	Active Safety Control Module																																																										
3	2016	Escalade ESV	Body	Video Processing Control Module																																																										
3	2016	Escalade ESV	Body	Radio																																																										
3	2016	Escalade ESV	Body	Amplifier																																																										
3	2016	Escalade ESV	Body	Media Disc Player																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																										
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																										
3	2016	Escalade ESV	Body	HVAC Control Module																																																										
3	2016	Escalade ESV	Body	Liftgate Control Module																																																										
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																										
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																										
3	2016	Escalade ESV	Body	Assist Step Control Module																																																										
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2016	Escalade ESV	Body	Frontview Camera Module																																																										
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																										
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
4	2011	ALL	Chassis	Electronic Brake Control Module																																																										
4	2011	ALL	Chassis	Electronic Suspension Control																																																										
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																										
4	2011	ALL	Body	Amplifier (Bose)																																																										
4	2011	ALL	Body	Assist Step Controller																																																										
4	2011	ALL	Body	Body Control Module																																																										
4	2011	ALL	Body	Body Control Module (aux.)																																																										
4	2011	ALL	Body	Driver Door Switch																																																										
4	2011	ALL	Body	HVAC Control Module																																																										
4	2011	ALL	Body	Inside Rear View Mirror Module																																																										
4	2011	ALL	Body	Instrument Panel Cluster																																																										
4	2011	ALL	Body	Left Side Object Detection Module																																																										
4	2011	ALL	Body	Lift Gate Module																																																										
4	2011	ALL	Body	Memory Seat Module																																																										
4	2011	ALL	Body	Park Assist Module																																																										
4	2011	ALL	Body	Passenger Door Switch																																																										
4	2011	ALL	Body	Passenger Presence System																																																										
4	2011	ALL	Body	Radio																																																										
4	2011	ALL	Body	Rear Heated Seat Module																																																										
4	2011	ALL	Body	Rear HVAC/RSA																																																										
4	2011	ALL	Body	Right Side Object Detection Module																																																										
4	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
4	2011	ALL	Body	Theft Deterrent Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
4	2012	ALL	Chassis	Electronic Brake Control Module																																																											
4	2012	ALL	Chassis	Electronic Suspension Control																																																											
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2012	ALL	Body	Amplifier (Bose)																																																											
4	2012	ALL	Body	Assist Step Controller																																																											
4	2012	ALL	Body	Body Control Module																																																											
4	2012	ALL	Body	Body Control Module (aux.)																																																											
4	2012	ALL	Body	Driver Door Switch																																																											
4	2012	ALL	Body	HVAC Control Module																																																											
4	2012	ALL	Body	Inside Rear View Mirror Module																																																											
4	2012	ALL	Body	Instrument Panel Cluster																																																											
4	2012	ALL	Body	Left Side Object Detection Module																																																											
4	2012	ALL	Body	Lift Gate Module																																																											
4	2012	ALL	Body	Memory Seat Module																																																											
4	2012	ALL	Body	Park Assist Module																																																											
4	2012	ALL	Body	Passenger Door Switch																																																											
4	2012	ALL	Body	Passenger Presence System																																																											
4	2012	ALL	Body	Radio																																																											
4	2012	ALL	Body	Rear Heated Seat Module																																																											
4	2012	ALL	Body	Rear HVAC/RSA																																																											
4	2012	ALL	Body	Right Side Object Detection Module																																																											
4	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
4	2012	ALL	Body	Theft Deterrent Module																																																											
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
4	2013	ALL	Chassis	Electronic Brake Control Module																																																											
4	2013	ALL	Chassis	Electronic Suspension Control																																																											
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2013	ALL	Body	Amplifier (Bose)																																																											
4	2013	ALL	Body	Assist Step Controller																																																											
4	2013	ALL	Body	Body Control Module																																																											
4	2013	ALL	Body	Body Control Module (aux.)																																																											
4	2013	ALL	Body	Driver Door Switch																																																											
4	2013	ALL	Body	HVAC Control Module																																																											
4	2013	ALL	Body	Inside Rear View Mirror Module																																																											
4	2013	ALL	Body	Instrument Panel Cluster																																																											
4	2013	ALL	Body	Left Side Object Detection Module																																																											
4	2013	ALL	Body	Lift Gate Module																																																											
4	2013	ALL	Body	Memory Seat Module																																																											
4	2013	ALL	Body	Park Assist Module																																																											
4	2013	ALL	Body	Passenger Door Switch																																																											
4	2013	ALL	Body	Passenger Presence System																																																											
4	2013	ALL	Body	Radio																																																											
4	2013	ALL	Body	Rear Heated Seat Module																																																											
4	2013	ALL	Body	Rear HVAC/RSA																																																											
4	2013	ALL	Body	Right Side Object Detection Module																																																											
4	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
4	2013	ALL	Body	Theft Deterrent Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade	Chassis	Suspension Control Module																																																										
4	2014	Escalade	Body	Body Control Module																																																										
4	2014	Escalade	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2014	Escalade	Body	Passenger Presence Module																																																										
4	2014	Escalade	Body	Instrument Cluster																																																										
4	2014	Escalade	Body	Radio																																																										
4	2014	Escalade	Body	Amplifier																																																										
4	2014	Escalade	Body	Rear Audio Control Module																																																										
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2014	Escalade	Body	HVAC Control Module																																																										
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Liftgate Control Module																																																										
4	2014	Escalade	Body	Seat Memory Control Module																																																										
4	2014	Escalade	Body	Rear Seat Heating Control Module																																																										
4	2014	Escalade	Body	Assist Step Control Module																																																										
4	2014	Escalade	Body	Right Side Object Detection Control Module																																																										
4	2014	Escalade	Body	Left Side Object Detection Control Module																																																										
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																																										
4	2014	Escalade	Body	Parking Assist Control Module																																																										
4	2014	Escalade	Body	Theft Deterrent Module																																																										
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2014	Escalade ESV	Body	Body Control Module																																																										
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2014	Escalade ESV	Body	Passenger Presence Module																																																										
4	2014	Escalade ESV	Body	Instrument Cluster																																																										
4	2014	Escalade ESV	Body	Radio																																																										
4	2014	Escalade ESV	Body	Amplifier																																																										
4	2014	Escalade ESV	Body	Rear Audio Control Module																																																										
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2014	Escalade ESV	Body	HVAC Control Module																																																										
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																										
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
4	2014	Escalade ESV	Body	Liftgate Control Module																																																								
4	2014	Escalade ESV	Body	Seat Memory Control Module																																																								
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																								
4	2014	Escalade ESV	Body	Assist Step Control Module																																																								
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																								
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																								
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																								
4	2014	Escalade ESV	Body	Parking Assist Control Module																																																								
4	2014	Escalade ESV	Body	Theft Deterrent Module																																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																								
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																								
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																								
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																								
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																								
4	2015	Escalade	Chassis	Electronic Brake Control Module																																																								
4	2015	Escalade	Chassis	Parking Brake Control Module																																																								
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																								
4	2015	Escalade	Chassis	Power Steering Control Module																																																								
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																								
4	2015	Escalade	Chassis	Suspension Control Module																																																								
4	2015	Escalade	Body	Body Control Module																																																								
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
4	2015	Escalade	Body	Passenger Presence Module																																																								
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																								
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																								
4	2015	Escalade	Body	Instrument Cluster																																																								
4	2015	Escalade	Body	Radio/HVAC Control																																																								
4	2015	Escalade	Body	Active Safety Control Module																																																								
4	2015	Escalade	Body	Video Processing Control Module																																																								
4	2015	Escalade	Body	Radio																																																								
4	2015	Escalade	Body	Amplifier																																																								
4	2015	Escalade	Body	Media Disc Player																																																								
4	2015	Escalade	Body	Human Machine Interface Control Module																																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																								
4	2015	Escalade	Body	HVAC Control Module																																																								
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																								
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																								
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																								
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																								
4	2015	Escalade	Body	Keyless Entry Control Module																																																								
4	2015	Escalade	Body	Assist Step Control Module																																																								
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
4	2015	Escalade	Body	Parking Assist Control Module																																																										
4	2015	Escalade	Body	Frontview Camera Module																																																											
4	2015	Escalade	Body	Steering Column Lock Control Module																																																											
4	2015	Escalade	Body	Battery Energy Control Module																																																											
4	2015	Escalade	Body	Long Range Radar Sensor Module																																																											
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																											
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																											
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																											
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																											
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																											
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																											
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																											
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																											
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																											
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																																											
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																											
4	2015	Escalade ESV	Chassis	Suspension Control Module																																																											
4	2015	Escalade ESV	Body	Body Control Module																																																											
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
4	2015	Escalade ESV	Body	Passenger Presence Module																																																											
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																											
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																											
4	2015	Escalade ESV	Body	Instrument Cluster																																																											
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																											
4	2015	Escalade ESV	Body	Active Safety Control Module																																																											
4	2015	Escalade ESV	Body	Video Processing Control Module																																																											
4	2015	Escalade ESV	Body	Radio																																																											
4	2015	Escalade ESV	Body	Amplifier																																																											
4	2015	Escalade ESV	Body	Media Disc Player																																																											
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																											
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																											
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																											
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																											
4	2015	Escalade ESV	Body	HVAC Control Module																																																											
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																											
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																											
4	2015	Escalade ESV	Body	Assist Step Control Module																																																											
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
4	2015	Escalade ESV	Body	Parking Assist Control Module																																																											
4	2015	Escalade ESV	Body	Frontview Camera Module																																																											
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
4	2016	Escalade	Chassis	Electronic Brake Control Module																																																										
4	2016	Escalade	Chassis	Parking Brake Control Module																																																										
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2016	Escalade	Chassis	Power Steering Control Module																																																										
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2016	Escalade	Chassis	Suspension Control Module																																																										
4	2016	Escalade	Body	Body Control Module																																																										
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2016	Escalade	Body	Passenger Presence Module																																																										
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2016	Escalade	Body	Instrument Cluster																																																										
4	2016	Escalade	Body	Radio/HVAC Control																																																										
4	2016	Escalade	Body	Active Safety Control Module																																																										
4	2016	Escalade	Body	Video Processing Control Module																																																										
4	2016	Escalade	Body	Radio																																																										
4	2016	Escalade	Body	Amplifier																																																										
4	2016	Escalade	Body	Media Disc Player																																																										
4	2016	Escalade	Body	Human Machine Interface Control Module																																																										
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																																										
4	2016	Escalade	Body	HVAC Control Module																																																										
4	2016	Escalade	Body	Liftgate Control Module																																																										
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																										
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																										
4	2016	Escalade	Body	Keyless Entry Control Module																																																										
4	2016	Escalade	Body	Assist Step Control Module																																																										
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																										
4	2016	Escalade	Body	Parking Assist Control Module																																																										
4	2016	Escalade	Body	Frontview Camera Module																																																										
4	2016	Escalade	Body	Steering Column Lock Control Module																																																										
4	2016	Escalade	Body	Long Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																										
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																											
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																																											
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																											
4	2016	Escalade ESV	Chassis	Suspension Control Module																																																											
4	2016	Escalade ESV	Body	Body Control Module																																																											
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
4	2016	Escalade ESV	Body	Passenger Presence Module																																																											
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																											
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																											
4	2016	Escalade ESV	Body	Instrument Cluster																																																											
4	2016	Escalade ESV	Body	Radio Control																																																											
4	2016	Escalade ESV	Body	HVAC Control																																																											
4	2016	Escalade ESV	Body	Active Safety Control Module																																																											
4	2016	Escalade ESV	Body	Video Processing Control Module																																																											
4	2016	Escalade ESV	Body	Radio																																																											
4	2016	Escalade ESV	Body	Amplifier																																																											
4	2016	Escalade ESV	Body	Media Disc Player																																																											
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																											
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																											
4	2016	Escalade ESV	Body	HVAC Control Module																																																											
4	2016	Escalade ESV	Body	Liftgate Control Module																																																											
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																											
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																											
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																											
4	2016	Escalade ESV	Body	Assist Step Control Module																																																											
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
4	2016	Escalade ESV	Body	Parking Assist Control Module																																																											
4	2016	Escalade ESV	Body	Frontview Camera Module																																																											
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																											
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																											
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																											
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																											
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																											
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																											
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																											
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																											
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																											
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																											
ALL	2004	Hearse	Chassis	DRP/ABS/TCS																																																											
ALL	2004	Hearse	Chassis	Magna Steer																																																											
ALL	2004	Hearse	Chassis	Rear Integration Module																																																											
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																											
ALL	2004	Hearse	Body	Amplifier (Delco)																																																											
ALL	2004	Hearse	Body	Dash Integration Module																																																											
ALL	2004	Hearse	Body	Driver Door Switch																																																											
ALL	2004	Hearse	Body	Driver Door Module																																																											
ALL	2004	Hearse	Body	Passenger Door Module																																																											
ALL	2004	Hearse	Body	Instrument Panel Cluster																																																											
ALL	2004	Hearse	Body	Instrument Panel Module																																																											
ALL	2004	Hearse	Body	Personalization																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
ALL	2004	Hearse	Body	Radio																																																									
ALL	2004	Hearse	Body	Rear Integration Module																																																									
ALL	2004	Hearse	Body	Remote Function Actuation																																																									
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																																																									
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																																									
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																									
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																									
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																									
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																									
ALL	2004	Limousine	Chassis	DRP/ABS/TCS																																																									
ALL	2004	Limousine	Chassis	Magna Steer																																																									
ALL	2004	Limousine	Chassis	Rear Integration Module																																																									
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																									
ALL	2004	Limousine	Body	Amplifier (Delco)																																																									
ALL	2004	Limousine	Body	Dash Integration Module																																																									
ALL	2004	Limousine	Body	Driver Door Switch																																																									
ALL	2004	Limousine	Body	Driver Door Module																																																									
ALL	2004	Limousine	Body	Passenger Door Module																																																									
ALL	2004	Limousine	Body	Left Mid Door Module																																																									
ALL	2004	Limousine	Body	Left Rear Door Module																																																									
ALL	2004	Limousine	Body	Right Mid Door Module																																																									
ALL	2004	Limousine	Body	Right Rear Door Module																																																									
ALL	2004	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2004	Limousine	Body	Instrument Panel Module																																																									
ALL	2004	Limousine	Body	Memory Seat Module																																																									
ALL	2004	Limousine	Body	Navigation Radio																																																									
ALL	2004	Limousine	Body	Personalization																																																									
ALL	2004	Limousine	Body	Radio																																																									
ALL	2004	Limousine	Body	Rear Climate Control Panel																																																									
ALL	2004	Limousine	Body	Rear Integration Module																																																									
ALL	2004	Limousine	Body	Remote Function Actuation																																																									
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																																																									
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																																									
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																									
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																									
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																									
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																									
ALL	2005	Hearse	Chassis	DRP/ABS/TCS																																																									
ALL	2005	Hearse	Chassis	Magna Steer																																																									
ALL	2005	Hearse	Chassis	Rear Integration Module																																																									
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																									
ALL	2005	Hearse	Body	Amplifier (Delco)																																																									
ALL	2005	Hearse	Body	Dash Integration Module																																																									
ALL	2005	Hearse	Body	Driver Door Switch																																																									
ALL	2005	Hearse	Body	Driver Door Module																																																									
ALL	2005	Hearse	Body	Passenger Door Module																																																									
ALL	2005	Hearse	Body	Instrument Panel Cluster																																																									
ALL	2005	Hearse	Body	Instrument Panel Module																																																									
ALL	2005	Hearse	Body	Personalization																																																									
ALL	2005	Hearse	Body	Radio																																																									
ALL	2005	Hearse	Body	Rear Integration Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
ALL	2005	Hearse	Body	Remote Function Actuation																																																									
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																																									
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																																									
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																									
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																									
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																									
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																									
ALL	2005	Limousine	Chassis	DRP/ABS/TCS																																																									
ALL	2005	Limousine	Chassis	Magna Steer																																																									
ALL	2005	Limousine	Chassis	Rear Integration Module																																																									
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																									
ALL	2005	Limousine	Body	Amplifier (Delco)																																																									
ALL	2005	Limousine	Body	Dash Integration Module																																																									
ALL	2005	Limousine	Body	Driver Door Switch																																																									
ALL	2005	Limousine	Body	Driver Door Module																																																									
ALL	2005	Limousine	Body	Passenger Door Module																																																									
ALL	2005	Limousine	Body	Left Mid Door Module																																																									
ALL	2005	Limousine	Body	Left Rear Door Module																																																									
ALL	2005	Limousine	Body	Right Mid Door Module																																																									
ALL	2005	Limousine	Body	Right Rear Door Module																																																									
ALL	2005	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2005	Limousine	Body	Instrument Panel Module																																																									
ALL	2005	Limousine	Body	Memory Seat Module																																																									
ALL	2005	Limousine	Body	Navigation Radio																																																									
ALL	2005	Limousine	Body	Personalization																																																									
ALL	2005	Limousine	Body	Radio																																																									
ALL	2005	Limousine	Body	Rear Climate Control Panel																																																									
ALL	2005	Limousine	Body	Rear Integration Module																																																									
ALL	2005	Limousine	Body	Remote Function Actuation																																																									
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint																																																									
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																																									
ALL	2006	Hearse	Powertrain	Engine Control Module																																																									
ALL	2006	Hearse	Powertrain	Transmission Control Module																																																									
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																																									
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																									
ALL	2006	Hearse	Body	Amplifier (Bose)																																																									
ALL	2006	Hearse	Body	Body Control Module																																																									
ALL	2006	Hearse	Body	Digital Radio Receiver																																																									
ALL	2006	Hearse	Body	Driver Door Switch																																																									
ALL	2006	Hearse	Body	Driver Position Module																																																									
ALL	2006	Hearse	Body	HVAC Control Module																																																									
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																									
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																									
ALL	2006	Hearse	Body	Passenger Door Switch																																																									
ALL	2006	Hearse	Body	Passenger Presence System																																																									
ALL	2006	Hearse	Body	Radio																																																									
ALL	2006	Hearse	Body	Rear Heated Seat Module																																																									
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																									
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																																									
ALL	2006	Hearse	Body	Theft Deterrent Module																																																									
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
ALL	2006	Limousine	Powertrain	Engine Control Module																																																									
ALL	2006	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2006	Limousine	Body	Amplifier (Bose)																																																										
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2006	Limousine	Body	Body Control Module																																																										
ALL	2006	Limousine	Body	Digital Radio Receiver																																																										
ALL	2006	Limousine	Body	Driver Door Switch																																																										
ALL	2006	Limousine	Body	Driver Position Module																																																										
ALL	2006	Limousine	Body	HVAC Control Module																																																										
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2006	Limousine	Body	Passenger Door Switch																																																										
ALL	2006	Limousine	Body	Passenger Presence System																																																										
ALL	2006	Limousine	Body	Radio																																																										
ALL	2006	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	Limousine	Body	Theft Deterrent Module																																																										
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																																										
ALL	2007	Hearse	Powertrain	Engine Control Module																																																										
ALL	2007	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Hearse	Body	Amplifier (Bose)																																																										
ALL	2007	Hearse	Body	Body Control Module																																																										
ALL	2007	Hearse	Body	Digital Radio Receiver																																																										
ALL	2007	Hearse	Body	Driver Door Switch																																																										
ALL	2007	Hearse	Body	Driver Position Module																																																										
ALL	2007	Hearse	Body	HVAC Control Module																																																										
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2007	Hearse	Body	Passenger Door Switch																																																										
ALL	2007	Hearse	Body	Passenger Presence System																																																										
ALL	2007	Hearse	Body	Radio																																																										
ALL	2007	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	Hearse	Body	Theft Deterrent Module																																																										
ALL	2007	Limousine	Powertrain	Engine Control Module																																																										
ALL	2007	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Limousine	Body	Amplifier (Bose)																																																										
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2007	Limousine	Body	Body Control Module																																																										
ALL	2007	Limousine	Body	Digital Radio Receiver																																																										
ALL	2007	Limousine	Body	Driver Door Switch																																																										
ALL	2007	Limousine	Body	Driver Position Module																																																										
ALL	2007	Limousine	Body	HVAC Control Module																																																										
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2007	Limousine	Body	Passenger Door Switch																																																											
ALL	2007	Limousine	Body	Passenger Presence System																																																											
ALL	2007	Limousine	Body	Radio																																																											
ALL	2007	Limousine	Body	Rear Heated Seat Module																																																											
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																																											
ALL	2007	Limousine	Body	Theft Deterrent Module																																																											
ALL	2008	Hearse	Powertrain	Engine Control Module																																																											
ALL	2008	Hearse	Powertrain	Transmission Control Module																																																											
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																											
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																																											
ALL	2008	Hearse	Body	Amplifier (Bose)																																																											
ALL	2008	Hearse	Body	Body Control Module																																																											
ALL	2008	Hearse	Body	Climate Control Seat Module																																																											
ALL	2008	Hearse	Body	Digital Radio Receiver																																																											
ALL	2008	Hearse	Body	Driver Door Switch																																																											
ALL	2008	Hearse	Body	Driver Position Module																																																											
ALL	2008	Hearse	Body	HVAC Control Module																																																											
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																											
ALL	2008	Hearse	Body	Passenger Door Switch																																																											
ALL	2008	Hearse	Body	Passenger Presence System																																																											
ALL	2008	Hearse	Body	Radio																																																											
ALL	2008	Hearse	Body	Rear Heated Seat Module																																																											
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																																											
ALL	2008	Hearse	Body	Theft Deterrent Module																																																											
ALL	2008	Limousine	Powertrain	Engine Control Module																																																											
ALL	2008	Limousine	Powertrain	Transmission Control Module																																																											
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																											
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																																											
ALL	2008	Limousine	Body	Amplifier (Bose)																																																											
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																											
ALL	2008	Limousine	Body	Body Control Module																																																											
ALL	2008	Limousine	Body	Climate Control Seat Module																																																											
ALL	2008	Limousine	Body	Digital Radio Receiver																																																											
ALL	2008	Limousine	Body	Driver Door Switch																																																											
ALL	2008	Limousine	Body	Driver Position Module																																																											
ALL	2008	Limousine	Body	HVAC Control Module																																																											
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2008	Limousine	Body	Passenger Door Switch																																																											
ALL	2008	Limousine	Body	Passenger Presence System																																																											
ALL	2008	Limousine	Body	Radio																																																											
ALL	2008	Limousine	Body	Rear Heated Seat Module																																																											
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																																											
ALL	2008	Limousine	Body	Theft Deterrent Module																																																											
ALL	2009	Hearse	Powertrain	Engine Control Module																																																											
ALL	2009	Hearse	Powertrain	Transmission Control Module																																																											
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																											
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																																											
ALL	2009	Hearse	Body	Amplifier (Bose)																																																											
ALL	2009	Hearse	Body	Body Control Module																																																											
ALL	2009	Hearse	Body	Climate Control Seat Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
ALL	2009	Hearse	Body	Digital Radio Receiver																																																									
ALL	2009	Hearse	Body	Driver Door Switch																																																										
ALL	2009	Hearse	Body	Driver Position Module																																																										
ALL	2009	Hearse	Body	HVAC Control Module																																																										
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2009	Hearse	Body	Passenger Door Switch																																																										
ALL	2009	Hearse	Body	Passenger Presence System																																																										
ALL	2009	Hearse	Body	Radio																																																										
ALL	2009	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	Hearse	Body	Theft Deterrent Module																																																										
ALL	2009	Limousine	Powertrain	Engine Control Module																																																										
ALL	2009	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2009	Limousine	Body	Amplifier (Bose)																																																										
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2009	Limousine	Body	Body Control Module																																																										
ALL	2009	Limousine	Body	Climate Control Seat Module																																																										
ALL	2009	Limousine	Body	Digital Radio Receiver																																																										
ALL	2009	Limousine	Body	Driver Door Switch																																																										
ALL	2009	Limousine	Body	Driver Position Module																																																										
ALL	2009	Limousine	Body	HVAC Control Module																																																										
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2009	Limousine	Body	Passenger Door Switch																																																										
ALL	2009	Limousine	Body	Passenger Presence System																																																										
ALL	2009	Limousine	Body	Radio																																																										
ALL	2009	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	Limousine	Body	Theft Deterrent Module																																																										
ALL	2010	Hearse	Powertrain	Engine Control Module																																																										
ALL	2010	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2010	Hearse	Body	Amplifier (Bose)																																																										
ALL	2010	Hearse	Body	Body Control Module																																																										
ALL	2010	Hearse	Body	Climate Control Seat Module																																																										
ALL	2010	Hearse	Body	Digital Radio Receiver																																																										
ALL	2010	Hearse	Body	Driver Door Switch																																																										
ALL	2010	Hearse	Body	Driver Position Module																																																										
ALL	2010	Hearse	Body	HVAC Control Module																																																										
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2010	Hearse	Body	Passenger Door Switch																																																										
ALL	2010	Hearse	Body	Passenger Presence System																																																										
ALL	2010	Hearse	Body	Radio																																																										
ALL	2010	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	Hearse	Body	Theft Deterrent Module																																																										
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	Limousine	Powertrain	Engine Control Module																																																										
ALL	2010	Limousine	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2010	Limousine	Body	Amplifier (Bose)																																																										
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2010	Limousine	Body	Body Control Module																																																										
ALL	2010	Limousine	Body	Climate Control Seat Module																																																										
ALL	2010	Limousine	Body	Digital Radio Receiver																																																										
ALL	2010	Limousine	Body	Driver Door Switch																																																										
ALL	2010	Limousine	Body	Driver Position Module																																																										
ALL	2010	Limousine	Body	HVAC Control Module																																																										
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2010	Limousine	Body	Passenger Door Switch																																																										
ALL	2010	Limousine	Body	Passenger Presence System																																																										
ALL	2010	Limousine	Body	Radio																																																										
ALL	2010	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	Limousine	Body	Theft Deterrent Module																																																										
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																																										
ALL	2011	Hearse	Powertrain	Engine Control Module																																																										
ALL	2011	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2011	Hearse	Body	Amplifier (Bose)																																																										
ALL	2011	Hearse	Body	Body Control Module																																																										
ALL	2011	Hearse	Body	Climate Control Seat Module																																																										
ALL	2011	Hearse	Body	Digital Radio Receiver																																																										
ALL	2011	Hearse	Body	Driver Door Switch																																																										
ALL	2011	Hearse	Body	Driver Position Module																																																										
ALL	2011	Hearse	Body	HVAC Control Module																																																										
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2011	Hearse	Body	Passenger Door Switch																																																										
ALL	2011	Hearse	Body	Passenger Presence System																																																										
ALL	2011	Hearse	Body	Radio																																																										
ALL	2011	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2011	Hearse	Body	Theft Deterrent Module																																																										
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																																										
ALL	2011	Limousine	Powertrain	Engine Control Module																																																										
ALL	2011	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2011	Limousine	Body	Amplifier (Bose)																																																										
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2011	Limousine	Body	Body Control Module																																																										
ALL	2011	Limousine	Body	Climate Control Seat Module																																																										
ALL	2011	Limousine	Body	Digital Radio Receiver																																																										
ALL	2011	Limousine	Body	Driver Door Switch																																																										
ALL	2011	Limousine	Body	Driver Position Module																																																										
ALL	2011	Limousine	Body	HVAC Control Module																																																										
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2011	Limousine	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
ALL	2011	Limousine	Body	Passenger Presence System																																																																
ALL	2011	Limousine	Body	Radio																																																																
ALL	2011	Limousine	Body	Rear Heated Seat Module																																																																
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																																																
ALL	2011	Limousine	Body	Theft Deterrent Module																																																																
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																																																

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Instrument Panel Cluster																																																										
C	2004	ALL	Body	OnStar																																																										
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Base Radio																																																										
C	2004	ALL	Body	Uplevel Radio																																																										
C	2004	ALL	Body	Navigation Radio																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																										
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																										
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	ESC																																																									
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2005	ALL	Chassis	VSES																																																									
C	2005	ALL	Body	Amplifier (Bose)																																																										
C	2005	ALL	Body	Body Control Module																																																										
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																																										
C	2005	ALL	Body	Driver Seat Module																																																										
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																									
C	2005	ALL	Body	Instrument Panel Cluster																																																								
C	2005	ALL	Body	Passenger Door Module																																																								
C	2005	ALL	Body	Passenger Presence System																																																								
C	2005	ALL	Body	Base Radio																																																								
C	2005	ALL	Body	Uplevel Radio																																																								
C	2005	ALL	Body	Navigation Radio																																																								
C	2005	ALL	Body	Rear Aux. Climate Module																																																								
C	2005	ALL	Body	Rear HVAC																																																								
C	2005	ALL	Body	Rear Seat Audio																																																						V			
C	2005	ALL	Body	Remote Function Actuation																																																								
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																								
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																								
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																								
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																								
C	2006	ALL	Chassis	ESC																																																								
C	2006	ALL	Chassis	Tire Pressure Monitor																																																								
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																								
C	2006	ALL	Chassis	VSES																																																								
C	2006	ALL	Body	Amplifier (Bose)																																																								
C	2006	ALL	Body	Body Control Module																																																								
C	2006	ALL	Body	CD Changer																																																								
C	2006	ALL	Body	Chime																																																								
C	2006	ALL	Body	Disc Player and Video Display																																																								
C	2006	ALL	Body	Driver Door Module																																																								
C	2006	ALL	Body	Driver Seat Module																																																								
C	2006	ALL	Body	Generator Battery Control Module																																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																								
C	2006	ALL	Body	Instrument Panel Cluster																																																								
C	2006	ALL	Body	Passenger Door Module																																																								
C	2006	ALL	Body	Passenger Presence System																																																								
C	2006	ALL	Body	Base Radio																																																								
C	2006	ALL	Body	Uplevel Radio																																																								
C	2006	ALL	Body	Navigation Radio																																																								
C	2006	ALL	Body	Rear Aux. Climate Module																																																								
C	2006	ALL	Body	Rear HVAC																																																								
C	2006	ALL	Body	Rear Seat Audio																																																							V			
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																								
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																								
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
C	2007	ALL	Chassis	Electronic Brake Control Module																																																								
C	2007	ALL	Chassis	Electronic Suspension Control																																																								
C	2007	ALL	Body	Amplifier (Bose)																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2007	ALL	Body	Assist Step Controller																																																											
C	2007	ALL	Body	Body Control Module																																																											
C	2007	ALL	Body	Body Control Module (aux.)																																																											
C	2007	ALL	Body	Digital Radio Receiver																																																											
C	2007	ALL	Body	Driver Door Switch																																																											
C	2007	ALL	Body	HVAC Control Module																																																											
C	2007	ALL	Body	Inside Rear View Mirror Module																																																											
C	2007	ALL	Body	Instrument Panel Cluster																																																											
C	2007	ALL	Body	Lift Gate Module																																																											
C	2007	ALL	Body	Memory Seat Module																																																											
C	2007	ALL	Body	Park Assist Module																																																											
C	2007	ALL	Body	Passenger Door Switch																																																											
C	2007	ALL	Body	Passenger Presence System																																																											
C	2007	ALL	Body	Radio																																																											
C	2007	ALL	Body	Rear Heated Seat Module																																																											
C	2007	ALL	Body	Rear HVAC/RSA																																																											
C	2007	ALL	Body	Rollover Sensor																																																											
C	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
C	2007	ALL	Body	Theft Deterrent Module																																																											
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
C	2008	ALL	Chassis	Electronic Brake Control Module																																																											
C	2008	ALL	Chassis	Electronic Suspension Control																																																											
C	2008	ALL	Chassis	Trailer Brake Control Module																																																											
C	2008	ALL	Body	Amplifier (Bose)																																																											
C	2008	ALL	Body	Assist Step Controller																																																											
C	2008	ALL	Body	Body Control Module																																																											
C	2008	ALL	Body	Body Control Module (aux.)																																																											
C	2008	ALL	Body	Digital Radio Receiver																																																											
C	2008	ALL	Body	Driver Door Switch																																																											
C	2008	ALL	Body	HVAC Control Module																																																											
C	2008	ALL	Body	Inside Rear View Mirror Module																																																											
C	2008	ALL	Body	Instrument Panel Cluster																																																											
C	2008	ALL	Body	Lift Gate Module																																																											
C	2008	ALL	Body	Memory Seat Module																																																											
C	2008	ALL	Body	Park Assist Module																																																											
C	2008	ALL	Body	Passenger Door Switch																																																											
C	2008	ALL	Body	Passenger Presence System																																																											
C	2008	ALL	Body	Radio																																																											
C	2008	ALL	Body	Rear Heated Seat Module																																																											
C	2008	ALL	Body	Rear HVAC/RSA																																																											
C	2008	ALL	Body	Rollover Sensor																																																											
C	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
C	2008	ALL	Body	Theft Deterrent Module																																																											
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2009	ALL	Chassis	Electronic Brake Control Module																																																											
C	2009	ALL	Chassis	Electronic Suspension Control																																																											
C	2009	ALL	Chassis	Trailer Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2009	ALL	Body	Amplifier (Bose)																																																											
C	2009	ALL	Body	Assist Step Controller																																																											
C	2009	ALL	Body	Body Control Module																																																											
C	2009	ALL	Body	Body Control Module (aux.)																																																											
C	2009	ALL	Body	Digital Radio Receiver																																																											
C	2009	ALL	Body	Driver Door Switch																																																											
C	2009	ALL	Body	HVAC Control Module																																																											
C	2009	ALL	Body	Inside Rear View Mirror Module																																																											
C	2009	ALL	Body	Instrument Panel Cluster																																																											
C	2009	ALL	Body	Left Side Object Detection Module																																																											
C	2009	ALL	Body	Lift Gate Module																																																											
C	2009	ALL	Body	Memory Seat Module																																																											
C	2009	ALL	Body	Park Assist Module																																																											
C	2009	ALL	Body	Passenger Door Switch																																																											
C	2009	ALL	Body	Passenger Presence System																																																											
C	2009	ALL	Body	Radio																																																											
C	2009	ALL	Body	Rear Heated Seat Module																																																											
C	2009	ALL	Body	Rear HVAC/RSA																																																											
C	2009	ALL	Body	Right Side Object Detection Module																																																											
C	2009	ALL	Body	Rollover Sensor																																																											
C	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
C	2009	ALL	Body	Theft Deterrent Module																																																											
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2010	ALL	Chassis	Electronic Brake Control Module																																																											
C	2010	ALL	Chassis	Electronic Suspension Control																																																											
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	ALL	Body	Amplifier (Bose)																																																											
C	2010	ALL	Body	Assist Step Controller																																																											
C	2010	ALL	Body	Body Control Module																																																											
C	2010	ALL	Body	Body Control Module (aux.)																																																											
C	2010	ALL	Body	Digital Radio Receiver																																																											
C	2010	ALL	Body	Driver Door Switch																																																											
C	2010	ALL	Body	HVAC Control Module																																																											
C	2010	ALL	Body	Inside Rear View Mirror Module																																																											
C	2010	ALL	Body	Instrument Panel Cluster																																																											
C	2010	ALL	Body	Left Side Object Detection Module																																																											
C	2010	ALL	Body	Lift Gate Module																																																											
C	2010	ALL	Body	Memory Seat Module																																																											
C	2010	ALL	Body	Park Assist Module																																																											
C	2010	ALL	Body	Passenger Door Switch																																																											
C	2010	ALL	Body	Passenger Presence System																																																											
C	2010	ALL	Body	Radio																																																											
C	2010	ALL	Body	Rear Heated Seat Module																																																											
C	2010	ALL	Body	Rear HVAC/RSA																																																											
C	2010	ALL	Body	Right Side Object Detection Module																																																											
C	2010	ALL	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2010	ALL	Body	Theft Deterrent Module																																																										
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																																										
E	2004	ALL	Chassis	Electronic Suspension Control																																																										
E	2004	ALL	Chassis	Tire Pressure Monitor																																																										
E	2004	ALL	Chassis	VES																																																										
E	2004	ALL	Body	Amplifier (Bose)																																																										
E	2004	ALL	Body	Amplifier (Delco)																																																										
E	2004	ALL	Body	Climate Control Panel																																																										
E	2004	ALL	Body	Dash Integration Module																																																										
E	2004	ALL	Body	Disc Player and Video Display																																																										
E	2004	ALL	Body	Driver Door Switch																																																										
E	2004	ALL	Body	Driver Door Module																																																										
E	2004	ALL	Body	Passenger Door Module																																																										
E	2004	ALL	Body	Left Rear Door Module																																																										
E	2004	ALL	Body	Right Rear Door Module																																																										
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2004	ALL	Body	Instrument Panel Cluster																																																										
E	2004	ALL	Body	Memory Seat Module																																																										
E	2004	ALL	Body	OnStar																																																										
E	2004	ALL	Body	Personalization																																																										
E	2004	ALL	Body	Base Radio																																																										
E	2004	ALL	Body	Navigation Radio																																																										
E	2004	ALL	Body	Rear Integration Module																																																										
E	2004	ALL	Body	Rear Seat Module																																																										
E	2004	ALL	Body	Remote Function Actuation																																																										
E	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2004	ALL	Body	TV Antenna Module																																																										
E	2004	ALL	Body	Vehicle Theft Deterrent																																																										
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																																										
E	2005	ALL	Chassis	Electronic Suspension Control																																																										
E	2005	ALL	Chassis	Tire Pressure Monitor																																																										
E	2005	ALL	Chassis	VES																																																										
E	2005	ALL	Body	Amplifier (Bose)																																																										
E	2005	ALL	Body	Amplifier (Delco)																																																										
E	2005	ALL	Body	Climate Control Panel																																																										
E	2005	ALL	Body	Dash Integration Module																																																										
E	2005	ALL	Body	Disc Player and Video Display																																																										
E	2005	ALL	Body	Driver Door Switch																																																										
E	2005	ALL	Body	Driver Door Module																																																										
E	2005	ALL	Body	Passenger Door Module																																																										
E	2005	ALL	Body	Left Rear Door Module																																																										
E	2005	ALL	Body	Right Rear Door Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																											
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																											
E	2005	ALL	Body	Instrument Panel Cluster																																																											
E	2005	ALL	Body	Memory Seat Module																																																											
E	2005	ALL	Body	Personalization																																																											
E	2005	ALL	Body	Base Radio																																																											
E	2005	ALL	Body	Navigation Radio																																																											
E	2005	ALL	Body	Rear Integration Module																																																											
E	2005	ALL	Body	Rear Seat Module																																																											
E	2005	ALL	Body	Remote Function Actuation																																																											
E	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
E	2005	ALL	Body	TV Antenna Module																																																											
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																											
E	2005	ALL	Body	Vehicle Theft Deterrent																																																											
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																											
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																											
E	2006	ALL	Chassis	Electronic Suspension Control																																																											
E	2006	ALL	Chassis	Tire Pressure Monitor																																																											
E	2006	ALL	Chassis	VES																																																											
E	2006	ALL	Body	Amplifier (Bose)																																																											
E	2006	ALL	Body	Amplifier (Delco)																																																											
E	2006	ALL	Body	Climate Control Panel																																																											
E	2006	ALL	Body	Dash Integration Module																																																											
E	2006	ALL	Body	Disc Player and Video Display																																																											
E	2006	ALL	Body	Driver Door Switch																																																											
E	2006	ALL	Body	Driver Door Module																																																											
E	2006	ALL	Body	Passenger Door Module																																																											
E	2006	ALL	Body	Left Rear Door Module																																																											
E	2006	ALL	Body	Right Rear Door Module																																																											
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																											
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																											
E	2006	ALL	Body	Instrument Panel Cluster																																																											
E	2006	ALL	Body	Lift Gate Module																																																											
E	2006	ALL	Body	Memory Seat Module																																																											
E	2006	ALL	Body	Personalization																																																											
E	2006	ALL	Body	Base Radio																																																											
E	2006	ALL	Body	Navigation Radio																																																											
E	2006	ALL	Body	Rear Integration Module																																																											
E	2006	ALL	Body	Rear Seat Module																																																											
E	2006	ALL	Body	Remote Function Actuation																																																											
E	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																											
E	2006	ALL	Body	Vehicle Theft Deterrent																																																											
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																											
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
E	2007	ALL	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
E	2007	ALL	Chassis	Electronic Suspension Control																																																											
E	2007	ALL	Body	Amplifier (Bose)																																																												
E	2007	ALL	Body	Body Control Module																																																											
E	2007	ALL	Body	Body Control Module (aux.)																																																											
E	2007	ALL	Body	Digital Radio Receiver																																																											
E	2007	ALL	Body	Driver Door Switch																																																											
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																											
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																											
E	2007	ALL	Body	HVAC Control Module																																																											
E	2007	ALL	Body	Instrument Panel Cluster																																																											
E	2007	ALL	Body	Lift Gate Module																																																											
E	2007	ALL	Body	Memory Seat Module																																																											
E	2007	ALL	Body	Park Assist Module																																																											
E	2007	ALL	Body	Passenger Door Switch																																																											
E	2007	ALL	Body	Passenger Presence System																																																											
E	2007	ALL	Body	Radio																																																											
E	2007	ALL	Body	Rear HVAC/RSA																																																											
E	2007	ALL	Body	Rear Seat Module																																																											
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																											
E	2007	ALL	Body	Rollover Sensor																																																											
E	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
E	2007	ALL	Body	Theft Deterrent Module																																																											
E	2007	ALL	Body	TV Antenna Module																																																											
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																											
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
E	2008	ALL	Chassis	Electronic Brake Control Module																																																											
E	2008	ALL	Chassis	Electronic Suspension Control																																																											
E	2008	ALL	Body	Amplifier (Bose)																																																											
E	2008	ALL	Body	Body Control Module																																																											
E	2008	ALL	Body	Body Control Module (aux.)																																																											
E	2008	ALL	Body	Digital Radio Receiver																																																											
E	2008	ALL	Body	Driver Door Switch																																																											
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																											
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																											
E	2008	ALL	Body	HVAC Control Module																																																											
E	2008	ALL	Body	Instrument Panel Cluster																																																											
E	2008	ALL	Body	Lift Gate Module																																																											
E	2008	ALL	Body	Memory Seat Module																																																											
E	2008	ALL	Body	Park Assist Module																																																											
E	2008	ALL	Body	Passenger Door Switch																																																											
E	2008	ALL	Body	Passenger Presence System																																																											
E	2008	ALL	Body	Radio																																																											
E	2008	ALL	Body	Rear HVAC/RSA																																																											
E	2008	ALL	Body	Rear Seat Module																																																											
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																											
E	2008	ALL	Body	Rollover Sensor																																																											
E	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
E	2008	ALL	Body	Theft Deterrent Module																																																											
E	2008	ALL	Body	TV Antenna Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																											
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																											
E	2009	ALL	Chassis	Electronic Brake Control Module																																																											
E	2009	ALL	Chassis	Electronic Suspension Control																																																											
E	2009	ALL	Body	Amplifier (Bose)																																																											
E	2009	ALL	Body	Body Control Module																																																										
E	2009	ALL	Body	Body Control Module (aux.)																																																										
E	2009	ALL	Body	Digital Radio Receiver																																																										
E	2009	ALL	Body	Driver Door Switch																																																										
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2009	ALL	Body	HVAC Control Module																																																										
E	2009	ALL	Body	Instrument Panel Cluster																																																										
E	2009	ALL	Body	Lift Gate Module																																																										
E	2009	ALL	Body	Memory Seat Module																																																										
E	2009	ALL	Body	Park Assist Module																																																										
E	2009	ALL	Body	Passenger Door Switch																																																										
E	2009	ALL	Body	Passenger Presence System																																																										
E	2009	ALL	Body	Radio																																																										
E	2009	ALL	Body	Rear HVAC/RSA																																																										
E	2009	ALL	Body	Rear Seat Module																																																										
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
E	2009	ALL	Body	Rollover Sensor																																																										
E	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2009	ALL	Body	Theft Deterrent Module																																																										
E	2009	ALL	Body	TV Antenna Module																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2004	ALL	Chassis	ESC																																																									
K	2004	ALL	Chassis	Rear Wheel Steering																																																										
K	2004	ALL	Chassis	Tire Pressure Monitor																																																										
K	2004	ALL	Chassis	VSES																																																										
K	2004	ALL	Body	Amplifier (Bose)																																																										
K	2004	ALL	Body	Body Control Module																																																										
K	2004	ALL	Body	CD Changer																																																										
K	2004	ALL	Body	Chime																																																										
K	2004	ALL	Body	Driver Door Module																																																										
K	2004	ALL	Body	Driver Seat Module																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2004	ALL	Body	Instrument Panel Cluster																																																										
K	2004	ALL	Body	OnStar																																																										
K	2004	ALL	Body	Passenger Door Module																																																										
K	2004	ALL	Body	Passenger Presence System																																																										
K	2004	ALL	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2004	ALL	Body	Uplevel Radio																																																										
K	2004	ALL	Body	Navigation Radio																																																										
K	2004	ALL	Body	Rear Aux. Climate Module																																																										
K	2004	ALL	Body	Rear HVAC																																																										
K	2004	ALL	Body	Rear Seat Audio																																																							V			
K	2004	ALL	Body	Rear Seat Entertainment																																																										
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	ESC																																																									
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	VSES																																																									
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																							V			
K	2005	ALL	Body	Remote Function Actuation																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2006	ALL	Chassis	ESC																																																									
K	2006	ALL	Chassis	Tire Pressure Monitor																																																										
K	2006	ALL	Chassis	VSES																																																									
K	2006	ALL	Body	Amplifier (Bose)																																																										
K	2006	ALL	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2006	ALL	Body	CD Changer																																																											
K	2006	ALL	Body	Chime																																																											
K	2006	ALL	Body	Disc Player and Video Display																																																												
K	2006	ALL	Body	Driver Door Module																																																												
K	2006	ALL	Body	Driver Seat Module																																																												
K	2006	ALL	Body	Generator Battery Control Module																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2006	ALL	Body	Instrument Panel Cluster																																																												
K	2006	ALL	Body	Passenger Door Module																																																												
K	2006	ALL	Body	Passenger Presence System																																																												
K	2006	ALL	Body	Base Radio																																																												
K	2006	ALL	Body	Uplevel Radio																																																												
K	2006	ALL	Body	Navigation Radio																																																												
K	2006	ALL	Body	Rear Aux. Climate Module																																																												
K	2006	ALL	Body	Rear HVAC																																																												
K	2006	ALL	Body	Rear Seat Audio																																																							V				
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2007	ALL	Chassis	Electronic Brake Control Module																																																												
K	2007	ALL	Chassis	Electronic Suspension Control																																																												
K	2007	ALL	Body	Amplifier (Bose)																																																												
K	2007	ALL	Body	Assist Step Controller																																																												
K	2007	ALL	Body	Body Control Module																																																												
K	2007	ALL	Body	Body Control Module (aux.)																																																												
K	2007	ALL	Body	Digital Radio Receiver																																																												
K	2007	ALL	Body	Driver Door Switch																																																												
K	2007	ALL	Body	HVAC Control Module																																																												
K	2007	ALL	Body	Inside Rear View Mirror Module																																																												
K	2007	ALL	Body	Instrument Panel Cluster																																																												
K	2007	ALL	Body	Lift Gate Module																																																												
K	2007	ALL	Body	Memory Seat Module																																																												
K	2007	ALL	Body	Park Assist Module																																																												
K	2007	ALL	Body	Passenger Door Switch																																																												
K	2007	ALL	Body	Passenger Presence System																																																												
K	2007	ALL	Body	Radio																																																												
K	2007	ALL	Body	Rear Heated Seat Module																																																												
K	2007	ALL	Body	Rear HVAC/RSA																																																												
K	2007	ALL	Body	Rollover Sensor																																																												
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2007	ALL	Body	Theft Deterrent Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2008	ALL	Chassis	Electronic Brake Control Module																																																												
K	2008	ALL	Chassis	Electronic Suspension Control																																																												
K	2008	ALL	Chassis	Trailer Brake Control Module																																																												
K	2008	ALL	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2008	ALL	Body	Assist Step Controller																																																											
K	2008	ALL	Body	Body Control Module																																																											
K	2008	ALL	Body	Body Control Module (aux.)																																																											
K	2008	ALL	Body	Digital Radio Receiver																																																											
K	2008	ALL	Body	Driver Door Switch																																																											
K	2008	ALL	Body	HVAC Control Module																																																											
K	2008	ALL	Body	Inside Rear View Mirror Module																																																											
K	2008	ALL	Body	Instrument Panel Cluster																																																											
K	2008	ALL	Body	Lift Gate Module																																																											
K	2008	ALL	Body	Memory Seat Module																																																											
K	2008	ALL	Body	Park Assist Module																																																											
K	2008	ALL	Body	Passenger Door Switch																																																											
K	2008	ALL	Body	Passenger Presence System																																																											
K	2008	ALL	Body	Radio																																																											
K	2008	ALL	Body	Rear Heated Seat Module																																																											
K	2008	ALL	Body	Rear HVAC/RSA																																																											
K	2008	ALL	Body	Rollover Sensor																																																											
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2008	ALL	Body	Theft Deterrent Module																																																											
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2009	ALL	Chassis	Electronic Brake Control Module																																																											
K	2009	ALL	Chassis	Electronic Suspension Control																																																											
K	2009	ALL	Chassis	Trailer Brake Control Module																																																											
K	2009	ALL	Body	Amplifier (Bose)																																																											
K	2009	ALL	Body	Assist Step Controller																																																											
K	2009	ALL	Body	Body Control Module																																																											
K	2009	ALL	Body	Body Control Module (aux.)																																																											
K	2009	ALL	Body	Digital Radio Receiver																																																											
K	2009	ALL	Body	Driver Door Switch																																																											
K	2009	ALL	Body	HVAC Control Module																																																											
K	2009	ALL	Body	Inside Rear View Mirror Module																																																											
K	2009	ALL	Body	Instrument Panel Cluster																																																											
K	2009	ALL	Body	Left Side Object Detection Module																																																											
K	2009	ALL	Body	Lift Gate Module																																																											
K	2009	ALL	Body	Memory Seat Module																																																											
K	2009	ALL	Body	Park Assist Module																																																											
K	2009	ALL	Body	Passenger Door Switch																																																											
K	2009	ALL	Body	Passenger Presence System																																																											
K	2009	ALL	Body	Radio																																																											
K	2009	ALL	Body	Rear Heated Seat Module																																																											
K	2009	ALL	Body	Rear HVAC/RSA																																																											
K	2009	ALL	Body	Right Side Object Detection Module																																																											
K	2009	ALL	Body	Rollover Sensor																																																											
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2009	ALL	Body	Theft Deterrent Module																																																											
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2010	ALL	Chassis	Electronic Brake Control Module																																																												
K	2010	ALL	Chassis	Electronic Suspension Control																																																												
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	ALL	Body	Amplifier (Bose)																																																												
K	2010	ALL	Body	Assist Step Controller																																																												
K	2010	ALL	Body	Body Control Module																																																												
K	2010	ALL	Body	Body Control Module (aux.)																																																												
K	2010	ALL	Body	Digital Radio Receiver																																																												
K	2010	ALL	Body	Driver Door Switch																																																												
K	2010	ALL	Body	HVAC Control Module																																																												
K	2010	ALL	Body	Inside Rear View Mirror Module																																																												
K	2010	ALL	Body	Instrument Panel Cluster																																																												
K	2010	ALL	Body	Left Side Object Detection Module																																																												
K	2010	ALL	Body	Lift Gate Module																																																												
K	2010	ALL	Body	Memory Seat Module																																																												
K	2010	ALL	Body	Park Assist Module																																																												
K	2010	ALL	Body	Passenger Door Switch																																																												
K	2010	ALL	Body	Passenger Presence System																																																												
K	2010	ALL	Body	Radio																																																												
K	2010	ALL	Body	Rear Heated Seat Module																																																												
K	2010	ALL	Body	Rear HVAC/RSA																																																												
K	2010	ALL	Body	Right Side Object Detection Module																																																												
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2010	ALL	Body	Theft Deterrent Module																																																												
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																												
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																												
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																												
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																												
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2010	SRX	Chassis	Electronic Brake Control Module																																																												
N	2010	SRX	Chassis	Parking Brake Control Module																																																												
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2010	SRX	Chassis	Suspension Control Module																																																												
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2010	SRX	Body	Passenger Presence Module																																																												
N	2010	SRX	Body	Instrument Cluster																																																												
N	2010	SRX	Body	Headlamp Control Module																																																												
N	2010	SRX	Body	Trailer Interface Control Module																																																												
N	2010	SRX	Body	Radio																																																												
N	2010	SRX	Body	Rear Audio Control Module																																																												
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																												
N	2010	SRX	Body	Multimedia Player Interface Module																																																												
N	2010	SRX	Body	Mobile Telephone Control Module																																																												
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																									
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																									
N	2010	SRX	Body	Liftgate Control Module																																																									
N	2010	SRX	Body	Seat Memory Control Module																																																									
N	2010	SRX	Body	Front Seat Heating Control Module																																																									
N	2010	SRX	Body	Rear Seat Heating Control Module																																																									
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																									
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
N	2010	SRX	Body	Parking Assist Control Module																																																									
N	2010	SRX	Body	Steering Column Lock Control Module																																																									
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																									
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																									
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																									
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																									
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																									
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																									
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2011	SRX	Chassis	Electronic Brake Control Module																																																									
N	2011	SRX	Chassis	Parking Brake Control Module																																																									
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2011	SRX	Chassis	Suspension Control Module																																																									
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2011	SRX	Body	Passenger Presence Module																																																									
N	2011	SRX	Body	Instrument Cluster																																																									
N	2011	SRX	Body	Headlamp Control Module																																																									
N	2011	SRX	Body	Trailer Interface Control Module																																																									
N	2011	SRX	Body	Radio																																																									
N	2011	SRX	Body	Rear Audio Control Module																																																									
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																									
N	2011	SRX	Body	Multimedia Player Interface Module																																																									
N	2011	SRX	Body	Mobile Telephone Control Module																																																									
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																									
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																									
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																									
N	2011	SRX	Body	Liftgate Control Module																																																									
N	2011	SRX	Body	Seat Memory Control Module																																																									
N	2011	SRX	Body	Front Seat Heating Control Module																																																									
N	2011	SRX	Body	Rear Seat Heating Control Module																																																									
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																									
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
N	2011	SRX	Body	Parking Assist Control Module																																																									
N	2011	SRX	Body	Steering Column Lock Control Module																																																									
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																									
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																											
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2012	SRX	Chassis	Electronic Brake Control Module																																																											
N	2012	SRX	Chassis	Parking Brake Control Module																																																											
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2012	SRX	Chassis	Suspension Control Module																																																											
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2012	SRX	Body	Passenger Presence Module																																																											
N	2012	SRX	Body	Instrument Cluster																																																											
N	2012	SRX	Body	Headlamp Control Module																																																											
N	2012	SRX	Body	Trailer Interface Control Module																																																											
N	2012	SRX	Body	Radio																																																											
N	2012	SRX	Body	Rear Audio Control Module																																																											
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																											
N	2012	SRX	Body	Multimedia Player Interface Module																																																											
N	2012	SRX	Body	Mobile Telephone Control Module																																																											
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																																											
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																											
N	2012	SRX	Body	Liftgate Control Module																																																											
N	2012	SRX	Body	Seat Memory Control Module																																																											
N	2012	SRX	Body	Front Seat Heating Control Module																																																											
N	2012	SRX	Body	Rear Seat Heating Control Module																																																											
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2012	SRX	Body	Parking Assist Control Module																																																											
N	2012	SRX	Body	Steering Column Lock Control Module																																																											
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2013	SRX	Chassis	Electronic Brake Control Module																																																											
N	2013	SRX	Chassis	Parking Brake Control Module																																																											
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2013	SRX	Chassis	Suspension Control Module																																																											
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2013	SRX	Body	Passenger Presence Module																																																											
N	2013	SRX	Body	Instrument Cluster																																																											
N	2013	SRX	Body	Radio/HVAC Control																																																											
N	2013	SRX	Body	Active Safety Control Module																																																											
N	2013	SRX	Body	Headlamp Control Module																																																											
N	2013	SRX	Body	Trailer Interface Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
N	2013	SRX	Body	Radio																																																											
N	2013	SRX	Body	Amplifier																																																											
N	2013	SRX	Body	Media Disc Player																																																											
N	2013	SRX	Body	Human Machine Interface Control Module																																																												
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																																												
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																																												
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
N	2013	SRX	Body	Liftgate Control Module																																																												
N	2013	SRX	Body	Seat Memory Control Module																																																												
N	2013	SRX	Body	Rear Seat Heating Control Module																																																												
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																												
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																												
N	2013	SRX	Body	Right Side Object Detection Control Module																																																												
N	2013	SRX	Body	Left Side Object Detection Control Module																																																												
N	2013	SRX	Body	Parking Assist Control Module																																																												
N	2013	SRX	Body	Frontview Camera Module																																																												
N	2013	SRX	Body	Steering Column Lock Control Module																																																												
N	2013	SRX	Body	Long Range Radar Sensor Module																																																												
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																												
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																												
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																												
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2014	SRX	Chassis	Electronic Brake Control Module																																																												
N	2014	SRX	Chassis	Parking Brake Control Module																																																												
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2014	SRX	Chassis	Suspension Control Module																																																												
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2014	SRX	Body	Passenger Presence Module																																																												
N	2014	SRX	Body	Instrument Cluster																																																												
N	2014	SRX	Body	Radio/HVAC Control																																																												
N	2014	SRX	Body	Active Safety Control Module																																																												
N	2014	SRX	Body	Headlamp Control Module																																																												
N	2014	SRX	Body	Trailer Interface Control Module																																																												
N	2014	SRX	Body	Radio																																																												
N	2014	SRX	Body	Amplifier																																																												
N	2014	SRX	Body	Media Disc Player																																																												
N	2014	SRX	Body	Human Machine Interface Control Module																																																												
N	2014	SRX	Body	Navigation Control Module																																																												
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																												
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																																												
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
N	2014	SRX	Body	Liftgate Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2014	SRX	Body	Rear Seat Heating Control Module																																																										
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2014	SRX	Body	Right Side Object Detection Control Module																																																										
N	2014	SRX	Body	Left Side Object Detection Control Module																																																										
N	2014	SRX	Body	Parking Assist Control Module																																																										
N	2014	SRX	Body	Frontview Camera Module																																																										
N	2014	SRX	Body	Steering Column Lock Control Module																																																										
N	2014	SRX	Body	Long Range Radar Sensor Module																																																										
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																										
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2015	SRX	Chassis	Electronic Brake Control Module																																																										
N	2015	SRX	Chassis	Parking Brake Control Module																																																										
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2015	SRX	Chassis	Suspension Control Module																																																										
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2015	SRX	Body	Passenger Presence Module																																																										
N	2015	SRX	Body	Instrument Cluster																																																										
N	2015	SRX	Body	Radio/HVAC Control																																																										
N	2015	SRX	Body	Active Safety Control Module																																																										
N	2015	SRX	Body	Headlamp Control Module																																																										
N	2015	SRX	Body	Trailer Interface Control Module																																																										
N	2015	SRX	Body	Radio																																																										
N	2015	SRX	Body	Amplifier																																																										
N	2015	SRX	Body	Rear Audio Control Module																																																										
N	2015	SRX	Body	Media Disc Player																																																										
N	2015	SRX	Body	Human Machine Interface Control Module																																																										
N	2015	SRX	Body	Navigation Control Module																																																										
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																										
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2015	SRX	Body	Liftgate Control Module																																																										
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2015	SRX	Body	Rear Seat Heating Control Module																																																										
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2015	SRX	Body	Right Side Object Detection Control Module																																																										
N	2015	SRX	Body	Left Side Object Detection Control Module																																																										
N	2015	SRX	Body	Parking Assist Control Module																																																										
N	2015	SRX	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
N	2015	SRX	Body	Steering Column Lock Control Module																																																											
N	2015	SRX	Body	Long Range Radar Sensor Module																																																												
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																											
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2016	SRX	Chassis	Electronic Brake Control Module																																																											
N	2016	SRX	Chassis	Parking Brake Control Module																																																											
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2016	SRX	Chassis	Suspension Control Module																																																											
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2016	SRX	Body	Passenger Presence Module																																																											
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																																											
N	2016	SRX	Body	Radio/HVAC Control																																																											
N	2016	SRX	Body	Active Safety Control Module																																																											
N	2016	SRX	Body	Headlamp Control Module																																																											
N	2016	SRX	Body	Trailer Interface Control Module																																																											
N	2016	SRX	Body	Radio																																																											
N	2016	SRX	Body	Amplifier																																																										
N	2016	SRX	Body	Rear Audio Control Module																																																											
N	2016	SRX	Body	Media Disc Player																																																											
N	2016	SRX	Body	Human Machine Interface Control Module																																																											
N	2016	SRX	Body	Navigation Control Module																																																											
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																											
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
N	2016	SRX	Body	Liftgate Control Module																																																											
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																											
N	2016	SRX	Body	Rear Seat Heating Control Module																																																											
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2016	SRX	Body	Right Side Object Detection Control Module																																																											
N	2016	SRX	Body	Left Side Object Detection Control Module																																																											
N	2016	SRX	Body	Parking Assist Control Module																																																											
N	2016	SRX	Body	Frontview Camera Module																																																											
N	2016	SRX	Body	Steering Column Lock Control Module																																																											
N	2016	SRX	Body	Long Range Radar Sensor Module																																																											
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																											
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
3	2011	ALL	Chassis	Electronic Brake Control Module																																																												
3	2011	ALL	Chassis	Electronic Suspension Control																																																												
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																												
3	2011	ALL	Body	Amplifier (Bose)																																																												
3	2011	ALL	Body	Assist Step Controller																																																												
3	2011	ALL	Body	Body Control Module																																																												
3	2011	ALL	Body	Body Control Module (aux.)																																																												
3	2011	ALL	Body	Digital Radio Receiver																																																												
3	2011	ALL	Body	Driver Door Switch																																																												
3	2011	ALL	Body	HVAC Control Module																																																												
3	2011	ALL	Body	Inside Rear View Mirror Module																																																												
3	2011	ALL	Body	Instrument Panel Cluster																																																												
3	2011	ALL	Body	Left Side Object Detection Module																																																												
3	2011	ALL	Body	Lift Gate Module																																																												
3	2011	ALL	Body	Memory Seat Module																																																												
3	2011	ALL	Body	Park Assist Module																																																												
3	2011	ALL	Body	Passenger Door Switch																																																												
3	2011	ALL	Body	Passenger Presence System																																																												
3	2011	ALL	Body	Radio																																																												
3	2011	ALL	Body	Rear Heated Seat Module																																																												
3	2011	ALL	Body	Rear HVAC/RSA																																																												
3	2011	ALL	Body	Right Side Object Detection Module																																																												
3	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
3	2011	ALL	Body	Theft Deterrent Module																																																												
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
3	2012	ALL	Chassis	Electronic Brake Control Module																																																												
3	2012	ALL	Chassis	Electronic Suspension Control																																																												
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																												
3	2012	ALL	Body	Amplifier (Bose)																																																												
3	2012	ALL	Body	Assist Step Controller																																																												
3	2012	ALL	Body	Body Control Module																																																												
3	2012	ALL	Body	Body Control Module (aux.)																																																												
3	2012	ALL	Body	Driver Door Switch																																																												
3	2012	ALL	Body	HVAC Control Module																																																												
3	2012	ALL	Body	Inside Rear View Mirror Module																																																												
3	2012	ALL	Body	Instrument Panel Cluster																																																												
3	2012	ALL	Body	Left Side Object Detection Module																																																												
3	2012	ALL	Body	Lift Gate Module																																																												
3	2012	ALL	Body	Memory Seat Module																																																												
3	2012	ALL	Body	Park Assist Module																																																												
3	2012	ALL	Body	Passenger Door Switch																																																												
3	2012	ALL	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
3	2012	ALL	Body	Radio																																																									
3	2012	ALL	Body	Rear Heated Seat Module																																																									
3	2012	ALL	Body	Rear HVAC/RSA																																																									
3	2012	ALL	Body	Right Side Object Detection Module																																																									
3	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
3	2012	ALL	Body	Theft Deterrent Module																																																									
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
3	2013	ALL	Chassis	Electronic Brake Control Module																																																									
3	2013	ALL	Chassis	Electronic Suspension Control																																																									
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																									
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																									
3	2013	ALL	Body	Amplifier (Bose)																																																									
3	2013	ALL	Body	Assist Step Controller																																																									
3	2013	ALL	Body	Body Control Module																																																									
3	2013	ALL	Body	Body Control Module (aux.)																																																									
3	2013	ALL	Body	Driver Door Switch																																																									
3	2013	ALL	Body	HVAC Control Module																																																									
3	2013	ALL	Body	Inside Rear View Mirror Module																																																									
3	2013	ALL	Body	Instrument Panel Cluster																																																									
3	2013	ALL	Body	Left Side Object Detection Module																																																									
3	2013	ALL	Body	Lift Gate Module																																																									
3	2013	ALL	Body	Memory Seat Module																																																									
3	2013	ALL	Body	Park Assist Module																																																									
3	2013	ALL	Body	Passenger Door Switch																																																									
3	2013	ALL	Body	Passenger Presence System																																																									
3	2013	ALL	Body	Radio																																																									
3	2013	ALL	Body	Rear Heated Seat Module																																																									
3	2013	ALL	Body	Rear HVAC/RSA																																																									
3	2013	ALL	Body	Right Side Object Detection Module																																																									
3	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
3	2013	ALL	Body	Theft Deterrent Module																																																									
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																									
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																									
3	2014	Escalade	Chassis	Suspension Control Module																																																									
3	2014	Escalade	Body	Body Control Module																																																									
3	2014	Escalade	Body	Auxiliary Body Control Module																																																									
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
3	2014	Escalade	Body	Passenger Presence Module																																																									
3	2014	Escalade	Body	Instrument Cluster																																																									
3	2014	Escalade	Body	Radio																																																									
3	2014	Escalade	Body	Amplifier																																																									
3	2014	Escalade	Body	Rear Audio Control Module																																																									
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																									
3	2014	Escalade	Body	Personal Audio Link Control Module																																																									
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																									
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
3	2014	Escalade	Body	HVAC Control Module																																										V														
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																							
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																							
3	2014	Escalade	Body	Liftgate Control Module																																																							
3	2014	Escalade	Body	Seat Memory Control Module																																																							
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																							
3	2014	Escalade	Body	Assist Step Control Module																																																							
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																							
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																							
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																							
3	2014	Escalade	Body	Parking Assist Control Module																																																							
3	2014	Escalade	Body	Theft Deterrent Module																																																							
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																							
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																							
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																							
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																							
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																							
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																							
3	2014	Escalade ESV	Body	Body Control Module																																																							
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																							
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
3	2014	Escalade ESV	Body	Passenger Presence Module																																																							
3	2014	Escalade ESV	Body	Instrument Cluster																																																							
3	2014	Escalade ESV	Body	Radio																																																							
3	2014	Escalade ESV	Body	Amplifier																																																							
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																							
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																							
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																							
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																							
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																							
3	2014	Escalade ESV	Body	HVAC Control Module																																										V														
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																							
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																							
3	2014	Escalade ESV	Body	Liftgate Control Module																																																							
3	2014	Escalade ESV	Body	Seat Memory Control Module																																																							
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																							
3	2014	Escalade ESV	Body	Assist Step Control Module																																																							
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																							
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																							
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																							
3	2014	Escalade ESV	Body	Parking Assist Control Module																																																							
3	2014	Escalade ESV	Body	Theft Deterrent Module																																																							
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																							
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																							
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																							
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																							
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																							
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																							
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																							
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																							
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																							

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																											
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																											
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																											
3	2015	Escalade	Chassis	Electronic Brake Control Module																																																											
3	2015	Escalade	Chassis	Parking Brake Control Module																																																											
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																											
3	2015	Escalade	Chassis	Power Steering Control Module																																																											
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																											
3	2015	Escalade	Chassis	Suspension Control Module																																																											
3	2015	Escalade	Body	Body Control Module																																																											
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
3	2015	Escalade	Body	Passenger Presence Module																																																											
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																											
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																											
3	2015	Escalade	Body	Instrument Cluster																																																											
3	2015	Escalade	Body	Radio/HVAC Control																																																											
3	2015	Escalade	Body	Active Safety Control Module																																																											
3	2015	Escalade	Body	Video Processing Control Module																																																											
3	2015	Escalade	Body	Radio																																																											
3	2015	Escalade	Body	Amplifier																																																											
3	2015	Escalade	Body	Media Disc Player																																																											
3	2015	Escalade	Body	Human Machine Interface Control Module																																																											
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																											
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																											
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																											
3	2015	Escalade	Body	HVAC Control Module																																																											
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																											
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																											
3	2015	Escalade	Body	Keyless Entry Control Module																																																											
3	2015	Escalade	Body	Assist Step Control Module																																																											
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																											
3	2015	Escalade	Body	Parking Assist Control Module																																																											
3	2015	Escalade	Body	Frontview Camera Module																																																											
3	2015	Escalade	Body	Steering Column Lock Control Module																																																											
3	2015	Escalade	Body	Battery Energy Control Module																																																											
3	2015	Escalade	Body	Long Range Radar Sensor Module																																																											
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																											
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																											
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																											
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																											
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																											
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																											
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																																										
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2015	Escalade ESV	Body	Body Control Module																																																										
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2015	Escalade ESV	Body	Passenger Presence Module																																																										
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2015	Escalade ESV	Body	Instrument Cluster																																																										
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																										
3	2015	Escalade ESV	Body	Active Safety Control Module																																																										
3	2015	Escalade ESV	Body	Video Processing Control Module																																																										
3	2015	Escalade ESV	Body	Radio																																																										
3	2015	Escalade ESV	Body	Amplifier																																																										
3	2015	Escalade ESV	Body	Media Disc Player																																																										
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2015	Escalade ESV	Body	HVAC Control Module																																																										
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																										
3	2015	Escalade ESV	Body	Assist Step Control Module																																																										
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2015	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2015	Escalade ESV	Body	Frontview Camera Module																																																										
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																										
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2016	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2016	Escalade	Chassis	Parking Brake Control Module																																																										
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2016	Escalade	Chassis	Power Steering Control Module																																																										
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2016	Escalade	Chassis	Suspension Control Module																																																										
3	2016	Escalade	Body	Body Control Module																																																										
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
3	2016	Escalade	Body	Passenger Presence Module																																																											
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																											
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																											
3	2016	Escalade	Body	Instrument Cluster																																																											
3	2016	Escalade	Body	Radio/HVAC Control																																																											
3	2016	Escalade	Body	Active Safety Control Module																																																											
3	2016	Escalade	Body	Video Processing Control Module																																																											
3	2016	Escalade	Body	Radio																																																											
3	2016	Escalade	Body	Amplifier																																																											
3	2016	Escalade	Body	Media Disc Player																																																											
3	2016	Escalade	Body	Human Machine Interface Control Module																																																											
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																																											
3	2016	Escalade	Body	HVAC Control Module																																																											
3	2016	Escalade	Body	Liftgate Control Module																																																											
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																											
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																											
3	2016	Escalade	Body	Keyless Entry Control Module																																																											
3	2016	Escalade	Body	Assist Step Control Module																																																											
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																											
3	2016	Escalade	Body	Parking Assist Control Module																																																											
3	2016	Escalade	Body	Frontview Camera Module																																																											
3	2016	Escalade	Body	Steering Column Lock Control Module																																																											
3	2016	Escalade	Body	Long Range Radar Sensor Module																																																											
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																											
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																											
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																											
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																											
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																											
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																											
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																											
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																																											
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																											
3	2016	Escalade ESV	Chassis	Suspension Control Module																																																											
3	2016	Escalade ESV	Body	Body Control Module																																																											
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
3	2016	Escalade ESV	Body	Passenger Presence Module																																																											
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																											
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																											
3	2016	Escalade ESV	Body	Instrument Cluster																																																											
3	2016	Escalade ESV	Body	Radio Control																																																											
3	2016	Escalade ESV	Body	HVAC Control																																																											
3	2016	Escalade ESV	Body	Active Safety Control Module																																																											
3	2016	Escalade ESV	Body	Video Processing Control Module																																																											
3	2016	Escalade ESV	Body	Radio																																																											
3	2016	Escalade ESV	Body	Amplifier																																																											
3	2016	Escalade ESV	Body	Media Disc Player																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																											
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																											
3	2016	Escalade ESV	Body	HVAC Control Module																																																											
3	2016	Escalade ESV	Body	Liftgate Control Module																																																											
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																											
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																											
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																											
3	2016	Escalade ESV	Body	Assist Step Control Module																																																											
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																											
3	2016	Escalade ESV	Body	Frontview Camera Module																																																											
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																											
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																											
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																											
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																											
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																											
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																											
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
4	2011	ALL	Chassis	Electronic Brake Control Module																																																											
4	2011	ALL	Chassis	Electronic Suspension Control																																																											
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2011	ALL	Body	Amplifier (Bose)																																																											
4	2011	ALL	Body	Assist Step Controller																																																											
4	2011	ALL	Body	Body Control Module																																																											
4	2011	ALL	Body	Body Control Module (aux.)																																																											
4	2011	ALL	Body	Driver Door Switch																																																											
4	2011	ALL	Body	HVAC Control Module																																																											
4	2011	ALL	Body	Inside Rear View Mirror Module																																																											
4	2011	ALL	Body	Instrument Panel Cluster																																																											
4	2011	ALL	Body	Left Side Object Detection Module																																																											
4	2011	ALL	Body	Lift Gate Module																																																											
4	2011	ALL	Body	Memory Seat Module																																																											
4	2011	ALL	Body	Park Assist Module																																																											
4	2011	ALL	Body	Passenger Door Switch																																																											
4	2011	ALL	Body	Passenger Presence System																																																											
4	2011	ALL	Body	Radio																																																											
4	2011	ALL	Body	Rear Heated Seat Module																																																											
4	2011	ALL	Body	Rear HVAC/RSA																																																											
4	2011	ALL	Body	Right Side Object Detection Module																																																											
4	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
4	2011	ALL	Body	Theft Deterrent Module																																																											
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
4	2012	ALL	Chassis	Electronic Brake Control Module																																																												
4	2012	ALL	Chassis	Electronic Suspension Control																																																											
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2012	ALL	Body	Amplifier (Bose)																																																											
4	2012	ALL	Body	Assist Step Controller																																																											
4	2012	ALL	Body	Body Control Module																																																											
4	2012	ALL	Body	Body Control Module (aux.)																																																											
4	2012	ALL	Body	Driver Door Switch																																																											
4	2012	ALL	Body	HVAC Control Module																																																											
4	2012	ALL	Body	Inside Rear View Mirror Module																																																											
4	2012	ALL	Body	Instrument Panel Cluster																																																											
4	2012	ALL	Body	Left Side Object Detection Module																																																											
4	2012	ALL	Body	Lift Gate Module																																																											
4	2012	ALL	Body	Memory Seat Module																																																											
4	2012	ALL	Body	Park Assist Module																																																											
4	2012	ALL	Body	Passenger Door Switch																																																											
4	2012	ALL	Body	Passenger Presence System																																																											
4	2012	ALL	Body	Radio																																																											
4	2012	ALL	Body	Rear Heated Seat Module																																																											
4	2012	ALL	Body	Rear HVAC/RSA																																																											
4	2012	ALL	Body	Right Side Object Detection Module																																																											
4	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
4	2012	ALL	Body	Theft Deterrent Module																																																											
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
4	2013	ALL	Chassis	Electronic Brake Control Module																																																											
4	2013	ALL	Chassis	Electronic Suspension Control																																																											
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2013	ALL	Body	Amplifier (Bose)																																																											
4	2013	ALL	Body	Assist Step Controller																																																											
4	2013	ALL	Body	Body Control Module																																																											
4	2013	ALL	Body	Body Control Module (aux.)																																																											
4	2013	ALL	Body	Driver Door Switch																																																											
4	2013	ALL	Body	HVAC Control Module																																																											
4	2013	ALL	Body	Inside Rear View Mirror Module																																																											
4	2013	ALL	Body	Instrument Panel Cluster																																																											
4	2013	ALL	Body	Left Side Object Detection Module																																																											
4	2013	ALL	Body	Lift Gate Module																																																											
4	2013	ALL	Body	Memory Seat Module																																																											
4	2013	ALL	Body	Park Assist Module																																																											
4	2013	ALL	Body	Passenger Door Switch																																																											
4	2013	ALL	Body	Passenger Presence System																																																											
4	2013	ALL	Body	Radio																																																											
4	2013	ALL	Body	Rear Heated Seat Module																																																											
4	2013	ALL	Body	Rear HVAC/RSA																																																											
4	2013	ALL	Body	Right Side Object Detection Module																																																											
4	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
4	2013	ALL	Body	Theft Deterrent Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																										
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade	Chassis	Suspension Control Module																																																										
4	2014	Escalade	Body	Body Control Module																																																										
4	2014	Escalade	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2014	Escalade	Body	Passenger Presence Module																																																										
4	2014	Escalade	Body	Instrument Cluster																																																										
4	2014	Escalade	Body	Radio																																																										
4	2014	Escalade	Body	Amplifier																																																										
4	2014	Escalade	Body	Rear Audio Control Module																																																										
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																										
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2014	Escalade	Body	HVAC Control Module																																									V																
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																										
4	2014	Escalade	Body	Liftgate Control Module																																																										
4	2014	Escalade	Body	Seat Memory Control Module																																																										
4	2014	Escalade	Body	Rear Seat Heating Control Module																																																										
4	2014	Escalade	Body	Assist Step Control Module																																																										
4	2014	Escalade	Body	Right Side Object Detection Control Module																																																										
4	2014	Escalade	Body	Left Side Object Detection Control Module																																																										
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																																										
4	2014	Escalade	Body	Parking Assist Control Module																																																										
4	2014	Escalade	Body	Theft Deterrent Module																																																										
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																										
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
4	2014	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2014	Escalade ESV	Body	Body Control Module																																																										
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																										
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2014	Escalade ESV	Body	Passenger Presence Module																																																										
4	2014	Escalade ESV	Body	Instrument Cluster																																																										
4	2014	Escalade ESV	Body	Radio																																																										
4	2014	Escalade ESV	Body	Amplifier																																																										
4	2014	Escalade ESV	Body	Rear Audio Control Module																																																										
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																										
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																										
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2014	Escalade ESV	Body	HVAC Control Module																																									V																
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																										
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
4	2014	Escalade ESV	Body	Liftgate Control Module																																																											
4	2014	Escalade ESV	Body	Seat Memory Control Module																																																											
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																											
4	2014	Escalade ESV	Body	Assist Step Control Module																																																											
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																											
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																											
4	2014	Escalade ESV	Body	Parking Assist Control Module																																																											
4	2014	Escalade ESV	Body	Theft Deterrent Module																																																											
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																											
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																											
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																											
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																											
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																											
4	2015	Escalade	Chassis	Electronic Brake Control Module																																																											
4	2015	Escalade	Chassis	Parking Brake Control Module																																																											
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																											
4	2015	Escalade	Chassis	Power Steering Control Module																																																											
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																											
4	2015	Escalade	Chassis	Suspension Control Module																																																											
4	2015	Escalade	Body	Body Control Module																																																											
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
4	2015	Escalade	Body	Passenger Presence Module																																																											
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																											
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																											
4	2015	Escalade	Body	Instrument Cluster																																																											
4	2015	Escalade	Body	Radio/HVAC Control																																																											
4	2015	Escalade	Body	Active Safety Control Module																																																											
4	2015	Escalade	Body	Video Processing Control Module																																																											
4	2015	Escalade	Body	Radio																																																											
4	2015	Escalade	Body	Amplifier																																																											
4	2015	Escalade	Body	Media Disc Player																																																											
4	2015	Escalade	Body	Human Machine Interface Control Module																																																											
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																											
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																											
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																											
4	2015	Escalade	Body	HVAC Control Module																																																											
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																											
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																											
4	2015	Escalade	Body	Keyless Entry Control Module																																																											
4	2015	Escalade	Body	Assist Step Control Module																																																											
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
4	2015	Escalade	Body	Parking Assist Control Module																																																										
4	2015	Escalade	Body	Frontview Camera Module																																																											
4	2015	Escalade	Body	Steering Column Lock Control Module																																																											
4	2015	Escalade	Body	Battery Energy Control Module																																																											
4	2015	Escalade	Body	Long Range Radar Sensor Module																																																											
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																											
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																											
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																											
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																											
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																											
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																											
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																											
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																											
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																											
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																																											
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																											
4	2015	Escalade ESV	Chassis	Suspension Control Module																																																											
4	2015	Escalade ESV	Body	Body Control Module																																																											
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
4	2015	Escalade ESV	Body	Passenger Presence Module																																																											
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																											
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																											
4	2015	Escalade ESV	Body	Instrument Cluster																																																											
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																											
4	2015	Escalade ESV	Body	Active Safety Control Module																																																											
4	2015	Escalade ESV	Body	Video Processing Control Module																																																											
4	2015	Escalade ESV	Body	Radio																																																											
4	2015	Escalade ESV	Body	Amplifier																																																											
4	2015	Escalade ESV	Body	Media Disc Player																																																											
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																											
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																											
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																											
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																											
4	2015	Escalade ESV	Body	HVAC Control Module																																																											
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																											
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																											
4	2015	Escalade ESV	Body	Assist Step Control Module																																																											
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
4	2015	Escalade ESV	Body	Parking Assist Control Module																																																											
4	2015	Escalade ESV	Body	Frontview Camera Module																																																											
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																											
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																											
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																											
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																											
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																											
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
4	2016	Escalade	Chassis	Electronic Brake Control Module																																																											
4	2016	Escalade	Chassis	Parking Brake Control Module																																																											
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																											
4	2016	Escalade	Chassis	Power Steering Control Module																																																											
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																											
4	2016	Escalade	Chassis	Suspension Control Module																																																											
4	2016	Escalade	Body	Body Control Module																																																											
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
4	2016	Escalade	Body	Passenger Presence Module																																																											
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																											
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																											
4	2016	Escalade	Body	Instrument Cluster																																																											
4	2016	Escalade	Body	Radio/HVAC Control																																																											
4	2016	Escalade	Body	Active Safety Control Module																																																											
4	2016	Escalade	Body	Video Processing Control Module																																																											
4	2016	Escalade	Body	Radio																																																											
4	2016	Escalade	Body	Amplifier																																																											
4	2016	Escalade	Body	Media Disc Player																																																											
4	2016	Escalade	Body	Human Machine Interface Control Module																																																											
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																																											
4	2016	Escalade	Body	HVAC Control Module																																																											
4	2016	Escalade	Body	Liftgate Control Module																																																											
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																											
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																											
4	2016	Escalade	Body	Keyless Entry Control Module																																																											
4	2016	Escalade	Body	Assist Step Control Module																																																											
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																											
4	2016	Escalade	Body	Parking Assist Control Module																																																											
4	2016	Escalade	Body	Frontview Camera Module																																																											
4	2016	Escalade	Body	Steering Column Lock Control Module																																																											
4	2016	Escalade	Body	Long Range Radar Sensor Module																																																											
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																											
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																											
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																											
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																											
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																											
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																											
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																																											
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																											
4	2016	Escalade ESV	Chassis	Suspension Control Module																																																											
4	2016	Escalade ESV	Body	Body Control Module																																																											
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
4	2016	Escalade ESV	Body	Passenger Presence Module																																																											
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																											
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																											
4	2016	Escalade ESV	Body	Instrument Cluster																																																											
4	2016	Escalade ESV	Body	Radio Control																																																											
4	2016	Escalade ESV	Body	HVAC Control																																																											
4	2016	Escalade ESV	Body	Active Safety Control Module																																																											
4	2016	Escalade ESV	Body	Video Processing Control Module																																																											
4	2016	Escalade ESV	Body	Radio																																																											
4	2016	Escalade ESV	Body	Amplifier																																																											
4	2016	Escalade ESV	Body	Media Disc Player																																																											
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																											
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																											
4	2016	Escalade ESV	Body	HVAC Control Module																																																											
4	2016	Escalade ESV	Body	Liftgate Control Module																																																											
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																											
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																											
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																											
4	2016	Escalade ESV	Body	Assist Step Control Module																																																											
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
4	2016	Escalade ESV	Body	Parking Assist Control Module																																																											
4	2016	Escalade ESV	Body	Frontview Camera Module																																																											
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																											
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																											
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																											
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																											
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																											
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																											
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																											
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																											
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																											
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																											
ALL	2004	Hearse	Chassis	DRP/ABS/TCS																																																											
ALL	2004	Hearse	Chassis	Magna Steer																																																											
ALL	2004	Hearse	Chassis	Rear Integration Module																																																											
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																											
ALL	2004	Hearse	Body	Amplifier (Delco)																																																											
ALL	2004	Hearse	Body	Dash Integration Module																																																											
ALL	2004	Hearse	Body	Driver Door Switch																																																											
ALL	2004	Hearse	Body	Driver Door Module																																																											
ALL	2004	Hearse	Body	Passenger Door Module																																																											
ALL	2004	Hearse	Body	Instrument Panel Cluster																																																											
ALL	2004	Hearse	Body	Instrument Panel Module																																																											
ALL	2004	Hearse	Body	Personalization																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
ALL	2004	Hearse	Body	Radio																																																												
ALL	2004	Hearse	Body	Rear Integration Module																																																												
ALL	2004	Hearse	Body	Remote Function Actuation																																																												
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																																												
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																												
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																												
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																												
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																												
ALL	2004	Limousine	Chassis	DRP/ABS/TCS																																																												
ALL	2004	Limousine	Chassis	Magna Steer																																																												
ALL	2004	Limousine	Chassis	Rear Integration Module																																																												
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																												
ALL	2004	Limousine	Body	Amplifier (Delco)																																																												
ALL	2004	Limousine	Body	Dash Integration Module																																																												
ALL	2004	Limousine	Body	Driver Door Switch																																																												
ALL	2004	Limousine	Body	Driver Door Module																																																												
ALL	2004	Limousine	Body	Passenger Door Module																																																												
ALL	2004	Limousine	Body	Left Mid Door Module																																																												
ALL	2004	Limousine	Body	Left Rear Door Module																																																												
ALL	2004	Limousine	Body	Right Mid Door Module																																																												
ALL	2004	Limousine	Body	Right Rear Door Module																																																												
ALL	2004	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2004	Limousine	Body	Instrument Panel Module																																																												
ALL	2004	Limousine	Body	Memory Seat Module																																																												
ALL	2004	Limousine	Body	Navigation Radio																																																												
ALL	2004	Limousine	Body	Personalization																																																												
ALL	2004	Limousine	Body	Radio																																																												
ALL	2004	Limousine	Body	Rear Climate Control Panel																																																												
ALL	2004	Limousine	Body	Rear Integration Module																																																												
ALL	2004	Limousine	Body	Remote Function Actuation																																																												
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																																												
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																												
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																												
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																												
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																												
ALL	2005	Hearse	Chassis	DRP/ABS/TCS																																																												
ALL	2005	Hearse	Chassis	Magna Steer																																																												
ALL	2005	Hearse	Chassis	Rear Integration Module																																																												
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																												
ALL	2005	Hearse	Body	Amplifier (Delco)																																																												
ALL	2005	Hearse	Body	Dash Integration Module																																																												
ALL	2005	Hearse	Body	Driver Door Switch																																																												
ALL	2005	Hearse	Body	Driver Door Module																																																												
ALL	2005	Hearse	Body	Passenger Door Module																																																												
ALL	2005	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2005	Hearse	Body	Instrument Panel Module																																																												
ALL	2005	Hearse	Body	Personalization																																																												
ALL	2005	Hearse	Body	Radio																																																												
ALL	2005	Hearse	Body	Rear Integration Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
ALL	2005	Hearse	Body	Remote Function Actuation																																																											
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																																											
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																																											
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																											
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																											
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																											
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																											
ALL	2005	Limousine	Chassis	DRP/ABS/TCS																																																											
ALL	2005	Limousine	Chassis	Magna Steer																																																											
ALL	2005	Limousine	Chassis	Rear Integration Module																																																											
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																											
ALL	2005	Limousine	Body	Amplifier (Delco)																																																											
ALL	2005	Limousine	Body	Dash Integration Module																																																											
ALL	2005	Limousine	Body	Driver Door Switch																																																											
ALL	2005	Limousine	Body	Driver Door Module																																																											
ALL	2005	Limousine	Body	Passenger Door Module																																																											
ALL	2005	Limousine	Body	Left Mid Door Module																																																											
ALL	2005	Limousine	Body	Left Rear Door Module																																																											
ALL	2005	Limousine	Body	Right Mid Door Module																																																											
ALL	2005	Limousine	Body	Right Rear Door Module																																																											
ALL	2005	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2005	Limousine	Body	Instrument Panel Module																																																											
ALL	2005	Limousine	Body	Memory Seat Module																																																											
ALL	2005	Limousine	Body	Navigation Radio																																																											
ALL	2005	Limousine	Body	Personalization																																																											
ALL	2005	Limousine	Body	Radio																																																											
ALL	2005	Limousine	Body	Rear Climate Control Panel																																																											
ALL	2005	Limousine	Body	Rear Integration Module																																																											
ALL	2005	Limousine	Body	Remote Function Actuation																																																											
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint																																																											
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																																											
ALL	2006	Hearse	Powertrain	Engine Control Module																																																											
ALL	2006	Hearse	Powertrain	Transmission Control Module																																																											
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																																											
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																											
ALL	2006	Hearse	Body	Amplifier (Bose)																																																											
ALL	2006	Hearse	Body	Body Control Module																																																											
ALL	2006	Hearse	Body	Digital Radio Receiver																																																											
ALL	2006	Hearse	Body	Driver Door Switch																																																											
ALL	2006	Hearse	Body	Driver Position Module																																																											
ALL	2006	Hearse	Body	HVAC Control Module																																																											
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																											
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																											
ALL	2006	Hearse	Body	Passenger Door Switch																																																											
ALL	2006	Hearse	Body	Passenger Presence System																																																											
ALL	2006	Hearse	Body	Radio																																																											
ALL	2006	Hearse	Body	Rear Heated Seat Module																																																											
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																											
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																																											
ALL	2006	Hearse	Body	Theft Deterrent Module																																																											
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
ALL	2006	Limousine	Powertrain	Engine Control Module																																																										
ALL	2006	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2006	Limousine	Body	Amplifier (Bose)																																																										
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2006	Limousine	Body	Body Control Module																																																										
ALL	2006	Limousine	Body	Digital Radio Receiver																																																										
ALL	2006	Limousine	Body	Driver Door Switch																																																										
ALL	2006	Limousine	Body	Driver Position Module																																																										
ALL	2006	Limousine	Body	HVAC Control Module																																																										
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2006	Limousine	Body	Passenger Door Switch																																																										
ALL	2006	Limousine	Body	Passenger Presence System																																																										
ALL	2006	Limousine	Body	Radio																																																										
ALL	2006	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	Limousine	Body	Theft Deterrent Module																																																										
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																																										
ALL	2007	Hearse	Powertrain	Engine Control Module																																																										
ALL	2007	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Hearse	Body	Amplifier (Bose)																																																										
ALL	2007	Hearse	Body	Body Control Module																																																										
ALL	2007	Hearse	Body	Digital Radio Receiver																																																										
ALL	2007	Hearse	Body	Driver Door Switch																																																										
ALL	2007	Hearse	Body	Driver Position Module																																																										
ALL	2007	Hearse	Body	HVAC Control Module																																																										
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2007	Hearse	Body	Passenger Door Switch																																																										
ALL	2007	Hearse	Body	Passenger Presence System																																																										
ALL	2007	Hearse	Body	Radio																																																										
ALL	2007	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	Hearse	Body	Theft Deterrent Module																																																										
ALL	2007	Limousine	Powertrain	Engine Control Module																																																										
ALL	2007	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Limousine	Body	Amplifier (Bose)																																																										
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2007	Limousine	Body	Body Control Module																																																										
ALL	2007	Limousine	Body	Digital Radio Receiver																																																										
ALL	2007	Limousine	Body	Driver Door Switch																																																										
ALL	2007	Limousine	Body	Driver Position Module																																																										
ALL	2007	Limousine	Body	HVAC Control Module																																																										
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2007	Limousine	Body	Passenger Door Switch																																																												
ALL	2007	Limousine	Body	Passenger Presence System																																																												
ALL	2007	Limousine	Body	Radio																																																												
ALL	2007	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2007	Limousine	Body	Theft Deterrent Module																																																												
ALL	2008	Hearse	Powertrain	Engine Control Module																																																												
ALL	2008	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2008	Hearse	Body	Amplifier (Bose)																																																												
ALL	2008	Hearse	Body	Body Control Module																																																												
ALL	2008	Hearse	Body	Climate Control Seat Module																																																												
ALL	2008	Hearse	Body	Digital Radio Receiver																																																												
ALL	2008	Hearse	Body	Driver Door Switch																																																												
ALL	2008	Hearse	Body	Driver Position Module																																																												
ALL	2008	Hearse	Body	HVAC Control Module																																																												
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2008	Hearse	Body	Passenger Door Switch																																																												
ALL	2008	Hearse	Body	Passenger Presence System																																																												
ALL	2008	Hearse	Body	Radio																																																												
ALL	2008	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2008	Hearse	Body	Theft Deterrent Module																																																												
ALL	2008	Limousine	Powertrain	Engine Control Module																																																												
ALL	2008	Limousine	Powertrain	Transmission Control Module																																																												
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																												
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																																												
ALL	2008	Limousine	Body	Amplifier (Bose)																																																												
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																												
ALL	2008	Limousine	Body	Body Control Module																																																												
ALL	2008	Limousine	Body	Climate Control Seat Module																																																												
ALL	2008	Limousine	Body	Digital Radio Receiver																																																												
ALL	2008	Limousine	Body	Driver Door Switch																																																												
ALL	2008	Limousine	Body	Driver Position Module																																																												
ALL	2008	Limousine	Body	HVAC Control Module																																																												
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2008	Limousine	Body	Passenger Door Switch																																																												
ALL	2008	Limousine	Body	Passenger Presence System																																																												
ALL	2008	Limousine	Body	Radio																																																												
ALL	2008	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2008	Limousine	Body	Theft Deterrent Module																																																												
ALL	2009	Hearse	Powertrain	Engine Control Module																																																												
ALL	2009	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2009	Hearse	Body	Amplifier (Bose)																																																												
ALL	2009	Hearse	Body	Body Control Module																																																												
ALL	2009	Hearse	Body	Climate Control Seat Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
ALL	2009	Hearse	Body	Digital Radio Receiver																																																											
ALL	2009	Hearse	Body	Driver Door Switch																																																												
ALL	2009	Hearse	Body	Driver Position Module																																																												
ALL	2009	Hearse	Body	HVAC Control Module																																																												
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2009	Hearse	Body	Passenger Door Switch																																																												
ALL	2009	Hearse	Body	Passenger Presence System																																																												
ALL	2009	Hearse	Body	Radio																																																												
ALL	2009	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2009	Hearse	Body	Theft Deterrent Module																																																												
ALL	2009	Limousine	Powertrain	Engine Control Module																																																												
ALL	2009	Limousine	Powertrain	Transmission Control Module																																																												
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																												
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																																												
ALL	2009	Limousine	Body	Amplifier (Bose)																																																												
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																												
ALL	2009	Limousine	Body	Body Control Module																																																												
ALL	2009	Limousine	Body	Climate Control Seat Module																																																												
ALL	2009	Limousine	Body	Digital Radio Receiver																																																												
ALL	2009	Limousine	Body	Driver Door Switch																																																												
ALL	2009	Limousine	Body	Driver Position Module																																																												
ALL	2009	Limousine	Body	HVAC Control Module																																																												
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2009	Limousine	Body	Passenger Door Switch																																																												
ALL	2009	Limousine	Body	Passenger Presence System																																																												
ALL	2009	Limousine	Body	Radio																																																												
ALL	2009	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2009	Limousine	Body	Theft Deterrent Module																																																												
ALL	2010	Hearse	Powertrain	Engine Control Module																																																												
ALL	2010	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2010	Hearse	Body	Amplifier (Bose)																																																												
ALL	2010	Hearse	Body	Body Control Module																																																												
ALL	2010	Hearse	Body	Climate Control Seat Module																																																												
ALL	2010	Hearse	Body	Digital Radio Receiver																																																												
ALL	2010	Hearse	Body	Driver Door Switch																																																												
ALL	2010	Hearse	Body	Driver Position Module																																																												
ALL	2010	Hearse	Body	HVAC Control Module																																																												
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2010	Hearse	Body	Passenger Door Switch																																																												
ALL	2010	Hearse	Body	Passenger Presence System																																																												
ALL	2010	Hearse	Body	Radio																																																												
ALL	2010	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2010	Hearse	Body	Theft Deterrent Module																																																												
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																																												
ALL	2010	Limousine	Powertrain	Engine Control Module																																																												
ALL	2010	Limousine	Powertrain	Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																											
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																																											
ALL	2010	Limousine	Body	Amplifier (Bose)																																																											
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																											
ALL	2010	Limousine	Body	Body Control Module																																																											
ALL	2010	Limousine	Body	Climate Control Seat Module																																																											
ALL	2010	Limousine	Body	Digital Radio Receiver																																																											
ALL	2010	Limousine	Body	Driver Door Switch																																																											
ALL	2010	Limousine	Body	Driver Position Module																																																											
ALL	2010	Limousine	Body	HVAC Control Module																																																											
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2010	Limousine	Body	Passenger Door Switch																																																											
ALL	2010	Limousine	Body	Passenger Presence System																																																											
ALL	2010	Limousine	Body	Radio																																																											
ALL	2010	Limousine	Body	Rear Heated Seat Module																																																											
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																																											
ALL	2010	Limousine	Body	Theft Deterrent Module																																																											
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																																											
ALL	2011	Hearse	Powertrain	Engine Control Module																																																											
ALL	2011	Hearse	Powertrain	Transmission Control Module																																																											
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																											
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																																											
ALL	2011	Hearse	Body	Amplifier (Bose)																																																											
ALL	2011	Hearse	Body	Body Control Module																																																											
ALL	2011	Hearse	Body	Climate Control Seat Module																																																											
ALL	2011	Hearse	Body	Digital Radio Receiver																																																											
ALL	2011	Hearse	Body	Driver Door Switch																																																											
ALL	2011	Hearse	Body	Driver Position Module																																																											
ALL	2011	Hearse	Body	HVAC Control Module																																																											
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																											
ALL	2011	Hearse	Body	Passenger Door Switch																																																											
ALL	2011	Hearse	Body	Passenger Presence System																																																											
ALL	2011	Hearse	Body	Radio																																																											
ALL	2011	Hearse	Body	Rear Heated Seat Module																																																											
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																																											
ALL	2011	Hearse	Body	Theft Deterrent Module																																																											
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																																											
ALL	2011	Limousine	Powertrain	Engine Control Module																																																											
ALL	2011	Limousine	Powertrain	Transmission Control Module																																																											
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																											
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																																											
ALL	2011	Limousine	Body	Amplifier (Bose)																																																											
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																											
ALL	2011	Limousine	Body	Body Control Module																																																											
ALL	2011	Limousine	Body	Climate Control Seat Module																																																											
ALL	2011	Limousine	Body	Digital Radio Receiver																																																											
ALL	2011	Limousine	Body	Driver Door Switch																																																											
ALL	2011	Limousine	Body	Driver Position Module																																																											
ALL	2011	Limousine	Body	HVAC Control Module																																																											
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2011	Limousine	Body	Passenger Door Switch																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
ALL	2011	Limousine	Body	Passenger Presence System																																																													
ALL	2011	Limousine	Body	Radio																																																													
ALL	2011	Limousine	Body	Rear Heated Seat Module																																																													
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																																													
ALL	2011	Limousine	Body	Theft Deterrent Module																																																													
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																																													

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																							
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																											
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2004	ALL	Chassis	ESC																																																										
C	2004	ALL	Chassis	Rear Wheel Steering																																																											
C	2004	ALL	Chassis	Tire Pressure Monitor																																																V										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																										
C	2004	ALL	Body	Amplifier (Bose)																							V																																				
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																								V																									V									
C	2004	ALL	Body	Heating and Air Conditioning Auto																								V																										V	V						
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																								V																										V	V						
C	2004	ALL	Body	Heating and Air Conditioning Manual																								V																										V	V						
C	2004	ALL	Body	Instrument Panel Cluster																V	V							V																																	
C	2004	ALL	Body	OnStar																																																									
C	2004	ALL	Body	Passenger Door Module																																																				V	V			
C	2004	ALL	Body	Passenger Presence System																																																					V		
C	2004	ALL	Body	Base Radio																																																								
C	2004	ALL	Body	Uplevel Radio																																																								
C	2004	ALL	Body	Navigation Radio																																																								
C	2004	ALL	Body	Rear Aux. Climate Module																								V																										V						V
C	2004	ALL	Body	Rear HVAC																																																								
C	2004	ALL	Body	Rear Seat Audio																																																								
C	2004	ALL	Body	Rear Seat Entertainment																																																								
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																						
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	ESC																																																										
C	2005	ALL	Chassis	Rear Wheel Steering																																																											
C	2005	ALL	Chassis	Tire Pressure Monitor																																																V										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2005	ALL	Chassis	VSES																																																										
C	2005	ALL	Body	Amplifier (Bose)																							V																																				
C	2005	ALL	Body	Body Control Module																																																										
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																																										
C	2005	ALL	Body	Driver Seat Module																								V																									V									
C	2005	ALL	Body	Generator Battery Control Module																																																											
C	2005	ALL	Body	Heating and Air Conditioning Auto																								V																										V	V						

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																								V																												V	V				
C	2005	ALL	Body	Heating and Air Conditioning Manual																								V																												V	V				
C	2005	ALL	Body	Instrument Panel Cluster																V	V							V																																	
C	2005	ALL	Body	Passenger Door Module																																																						V	V	
C	2005	ALL	Body	Passenger Presence System																																																							V	
C	2005	ALL	Body	Base Radio																																																							
C	2005	ALL	Body	Uplevel Radio																																																							
C	2005	ALL	Body	Navigation Radio																																																							
C	2005	ALL	Body	Rear Aux. Climate Module																								V																												V					V
C	2005	ALL	Body	Rear HVAC																																																							
C	2005	ALL	Body	Rear Seat Audio																																																							
C	2005	ALL	Body	Remote Function Actuation																																																							
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																							
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																							
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																							
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																					
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																							
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																							
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																							
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																							
C	2006	ALL	Chassis	ESC																																																						
C	2006	ALL	Chassis	Tire Pressure Monitor																																															V								
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																							
C	2006	ALL	Chassis	VSES																																																						
C	2006	ALL	Body	Amplifier (Bose)																							V																																	
C	2006	ALL	Body	Body Control Module																																																							
C	2006	ALL	Body	CD Changer																																																							
C	2006	ALL	Body	Chime																																																							
C	2006	ALL	Body	Disc Player and Video Display																																																							
C	2006	ALL	Body	Driver Door Module																																																							
C	2006	ALL	Body	Driver Seat Module																								V																										V							
C	2006	ALL	Body	Generator Battery Control Module																																																							
C	2006	ALL	Body	Heating and Air Conditioning Auto																								V																												V	V				
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																								V																												V	V				
C	2006	ALL	Body	Heating and Air Conditioning Manual																								V																												V	V				
C	2006	ALL	Body	Instrument Panel Cluster																V	V							V																																	
C	2006	ALL	Body	Passenger Door Module																																																						V	V	
C	2006	ALL	Body	Passenger Presence System																																																							V	
C	2006	ALL	Body	Base Radio																																																							
C	2006	ALL	Body	Uplevel Radio																																																							
C	2006	ALL	Body	Navigation Radio																																																							
C	2006	ALL	Body	Rear Aux. Climate Module																								V																												V					V
C	2006	ALL	Body	Rear HVAC																																																							
C	2006	ALL	Body	Rear Seat Audio																																																							
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																							
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																							
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module				V							V																																													
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
C	2007	ALL	Chassis	Electronic Brake Control Module																																																								
C	2007	ALL	Chassis	Electronic Suspension Control																																																								
C	2007	ALL	Body	Amplifier (Bose)																																																							

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2007	ALL	Body	Assist Step Controller																																																								
C	2007	ALL	Body	Body Control Module																																																								
C	2007	ALL	Body	Body Control Module (aux.)																																																								
C	2007	ALL	Body	Digital Radio Receiver																																																								
C	2007	ALL	Body	Driver Door Switch																																																								
C	2007	ALL	Body	HVAC Control Module																																																								
C	2007	ALL	Body	Inside Rear View Mirror Module																																																								
C	2007	ALL	Body	Instrument Panel Cluster																																																								
C	2007	ALL	Body	Lift Gate Module																																																								
C	2007	ALL	Body	Memory Seat Module																																																								
C	2007	ALL	Body	Park Assist Module																																																								
C	2007	ALL	Body	Passenger Door Switch																																																								
C	2007	ALL	Body	Passenger Presence System																																																								
C	2007	ALL	Body	Radio																																																								
C	2007	ALL	Body	Rear Heated Seat Module																																																								
C	2007	ALL	Body	Rear HVAC/RSA																																																								
C	2007	ALL	Body	Rollover Sensor																																																								
C	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2007	ALL	Body	Theft Deterrent Module																																																								
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																													
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
C	2008	ALL	Chassis	Electronic Brake Control Module																																																								
C	2008	ALL	Chassis	Electronic Suspension Control																																																								
C	2008	ALL	Chassis	Trailer Brake Control Module																																																								
C	2008	ALL	Body	Amplifier (Bose)																																																								
C	2008	ALL	Body	Assist Step Controller																																																								
C	2008	ALL	Body	Body Control Module																																																								
C	2008	ALL	Body	Body Control Module (aux.)																																																								
C	2008	ALL	Body	Digital Radio Receiver																																																								
C	2008	ALL	Body	Driver Door Switch																																																								
C	2008	ALL	Body	HVAC Control Module																																																								
C	2008	ALL	Body	Inside Rear View Mirror Module																																																								
C	2008	ALL	Body	Instrument Panel Cluster																																																								
C	2008	ALL	Body	Lift Gate Module																																																								
C	2008	ALL	Body	Memory Seat Module																																																								
C	2008	ALL	Body	Park Assist Module																																																								
C	2008	ALL	Body	Passenger Door Switch																																																								
C	2008	ALL	Body	Passenger Presence System																																																								
C	2008	ALL	Body	Radio																																																								
C	2008	ALL	Body	Rear Heated Seat Module																																																								
C	2008	ALL	Body	Rear HVAC/RSA																																																								
C	2008	ALL	Body	Rollover Sensor																																																								
C	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2008	ALL	Body	Theft Deterrent Module																																																								
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2009	ALL	Chassis	Electronic Brake Control Module																																																								
C	2009	ALL	Chassis	Electronic Suspension Control																																																								
C	2009	ALL	Chassis	Trailer Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2009	ALL	Body	Amplifier (Bose)																																																								
C	2009	ALL	Body	Assist Step Controller																																																								
C	2009	ALL	Body	Body Control Module																																																								
C	2009	ALL	Body	Body Control Module (aux.)																																																								
C	2009	ALL	Body	Digital Radio Receiver																																																								
C	2009	ALL	Body	Driver Door Switch																																																								
C	2009	ALL	Body	HVAC Control Module																																																								
C	2009	ALL	Body	Inside Rear View Mirror Module																																																								
C	2009	ALL	Body	Instrument Panel Cluster																																																								
C	2009	ALL	Body	Left Side Object Detection Module																																																								
C	2009	ALL	Body	Lift Gate Module																																																								
C	2009	ALL	Body	Memory Seat Module																																																								
C	2009	ALL	Body	Park Assist Module																																																								
C	2009	ALL	Body	Passenger Door Switch																																																								
C	2009	ALL	Body	Passenger Presence System																																																								
C	2009	ALL	Body	Radio																																																								
C	2009	ALL	Body	Rear Heated Seat Module																																																								
C	2009	ALL	Body	Rear HVAC/RSA																																																								
C	2009	ALL	Body	Right Side Object Detection Module																																																								
C	2009	ALL	Body	Rollover Sensor																																																								
C	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2009	ALL	Body	Theft Deterrent Module																																																								
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																														
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2010	ALL	Chassis	Electronic Brake Control Module																																																								
C	2010	ALL	Chassis	Electronic Suspension Control																																																								
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	ALL	Body	Amplifier (Bose)																																																								
C	2010	ALL	Body	Assist Step Controller																																																								
C	2010	ALL	Body	Body Control Module																																																								
C	2010	ALL	Body	Body Control Module (aux.)																																																								
C	2010	ALL	Body	Digital Radio Receiver																																																								
C	2010	ALL	Body	Driver Door Switch																																																								
C	2010	ALL	Body	HVAC Control Module																																																								
C	2010	ALL	Body	Inside Rear View Mirror Module																																																								
C	2010	ALL	Body	Instrument Panel Cluster																																																								
C	2010	ALL	Body	Left Side Object Detection Module																																																								
C	2010	ALL	Body	Lift Gate Module																																																								
C	2010	ALL	Body	Memory Seat Module																																																								
C	2010	ALL	Body	Park Assist Module																																																								
C	2010	ALL	Body	Passenger Door Switch																																																								
C	2010	ALL	Body	Passenger Presence System																																																								
C	2010	ALL	Body	Radio																																																								
C	2010	ALL	Body	Rear Heated Seat Module																																																								
C	2010	ALL	Body	Rear HVAC/RSA																																																								
C	2010	ALL	Body	Right Side Object Detection Module																																																								
C	2010	ALL	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2010	ALL	Body	Theft Deterrent Module																																																								
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																								
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																																								
E	2004	ALL	Chassis	Electronic Suspension Control																																																								
E	2004	ALL	Chassis	Tire Pressure Monitor																																																								
E	2004	ALL	Chassis	VES																																																								
E	2004	ALL	Body	Amplifier (Bose)																																																								
E	2004	ALL	Body	Amplifier (Delco)																																																								
E	2004	ALL	Body	Climate Control Panel																																																								
E	2004	ALL	Body	Dash Integration Module																																																								
E	2004	ALL	Body	Disc Player and Video Display																																																								
E	2004	ALL	Body	Driver Door Switch																																																								
E	2004	ALL	Body	Driver Door Module																																																								
E	2004	ALL	Body	Passenger Door Module																																																								
E	2004	ALL	Body	Left Rear Door Module																																																								
E	2004	ALL	Body	Right Rear Door Module																																																								
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																								
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																								
E	2004	ALL	Body	Instrument Panel Cluster																																																								
E	2004	ALL	Body	Memory Seat Module																																																								
E	2004	ALL	Body	OnStar																																																								
E	2004	ALL	Body	Personalization																																																								
E	2004	ALL	Body	Base Radio																																																								
E	2004	ALL	Body	Navigation Radio																																																								
E	2004	ALL	Body	Rear Integration Module																																																								
E	2004	ALL	Body	Rear Seat Module																																																								
E	2004	ALL	Body	Remote Function Actuation																																																								
E	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
E	2004	ALL	Body	TV Antenna Module																																																								
E	2004	ALL	Body	Vehicle Theft Deterrent																																																								
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																								
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																																								
E	2005	ALL	Chassis	Electronic Suspension Control																																																								
E	2005	ALL	Chassis	Tire Pressure Monitor																																																								
E	2005	ALL	Chassis	VES																																																								
E	2005	ALL	Body	Amplifier (Bose)																																																								
E	2005	ALL	Body	Amplifier (Delco)																																																								
E	2005	ALL	Body	Climate Control Panel																																																								
E	2005	ALL	Body	Dash Integration Module																																																								
E	2005	ALL	Body	Disc Player and Video Display																																																								
E	2005	ALL	Body	Driver Door Switch																																																								
E	2005	ALL	Body	Driver Door Module																																																								
E	2005	ALL	Body	Passenger Door Module																																																								
E	2005	ALL	Body	Left Rear Door Module																																																								
E	2005	ALL	Body	Right Rear Door Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																								
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																									
E	2005	ALL	Body	Instrument Panel Cluster																																																									
E	2005	ALL	Body	Memory Seat Module																																																									
E	2005	ALL	Body	Personalization																																																									
E	2005	ALL	Body	Base Radio																																																									
E	2005	ALL	Body	Navigation Radio																																																									
E	2005	ALL	Body	Rear Integration Module																																																									
E	2005	ALL	Body	Rear Seat Module																																																									
E	2005	ALL	Body	Remote Function Actuation																																																									
E	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
E	2005	ALL	Body	TV Antenna Module																																																									
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																									
E	2005	ALL	Body	Vehicle Theft Deterrent																																																									
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																									
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																									
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																									
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																									
E	2006	ALL	Chassis	Electronic Suspension Control																																																									
E	2006	ALL	Chassis	Tire Pressure Monitor																																																									
E	2006	ALL	Chassis	VES																																																									
E	2006	ALL	Body	Amplifier (Bose)																																																									
E	2006	ALL	Body	Amplifier (Delco)																																																									
E	2006	ALL	Body	Climate Control Panel																																																									
E	2006	ALL	Body	Dash Integration Module																																																									
E	2006	ALL	Body	Disc Player and Video Display																																																									
E	2006	ALL	Body	Driver Door Switch																																																									
E	2006	ALL	Body	Driver Door Module																																																									
E	2006	ALL	Body	Passenger Door Module																																																									
E	2006	ALL	Body	Left Rear Door Module																																																									
E	2006	ALL	Body	Right Rear Door Module																																																									
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																									
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																									
E	2006	ALL	Body	Instrument Panel Cluster																																																									
E	2006	ALL	Body	Lift Gate Module																																																									
E	2006	ALL	Body	Memory Seat Module																																																									
E	2006	ALL	Body	Personalization																																																									
E	2006	ALL	Body	Base Radio																																																									
E	2006	ALL	Body	Navigation Radio																																																									
E	2006	ALL	Body	Rear Integration Module																																																									
E	2006	ALL	Body	Rear Seat Module																																																									
E	2006	ALL	Body	Remote Function Actuation																																																									
E	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																									
E	2006	ALL	Body	Vehicle Theft Deterrent																																																									
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																									
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																									
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																									
E	2007	ALL	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
E	2007	ALL	Chassis	Electronic Suspension Control																																																								
E	2007	ALL	Body	Amplifier (Bose)																																																								
E	2007	ALL	Body	Body Control Module																																																								
E	2007	ALL	Body	Body Control Module (aux.)																																																								
E	2007	ALL	Body	Digital Radio Receiver																																																								
E	2007	ALL	Body	Driver Door Switch																																																								
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																								
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																								
E	2007	ALL	Body	HVAC Control Module																																																								
E	2007	ALL	Body	Instrument Panel Cluster																																																								
E	2007	ALL	Body	Lift Gate Module																																																								
E	2007	ALL	Body	Memory Seat Module																																																								
E	2007	ALL	Body	Park Assist Module																																																								
E	2007	ALL	Body	Passenger Door Switch																																																								
E	2007	ALL	Body	Passenger Presence System																																																								
E	2007	ALL	Body	Radio																																																								
E	2007	ALL	Body	Rear HVAC/RSA																																																								
E	2007	ALL	Body	Rear Seat Module																																																								
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																								
E	2007	ALL	Body	Rollover Sensor																																																								
E	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
E	2007	ALL	Body	Theft Deterrent Module																																																								
E	2007	ALL	Body	TV Antenna Module																																																								
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																								
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
E	2008	ALL	Chassis	Electronic Brake Control Module																																																								
E	2008	ALL	Chassis	Electronic Suspension Control																																																								
E	2008	ALL	Body	Amplifier (Bose)																																																								
E	2008	ALL	Body	Body Control Module																																																								
E	2008	ALL	Body	Body Control Module (aux.)																																																								
E	2008	ALL	Body	Digital Radio Receiver																																																								
E	2008	ALL	Body	Driver Door Switch																																																								
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																								
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																								
E	2008	ALL	Body	HVAC Control Module																																																								
E	2008	ALL	Body	Instrument Panel Cluster																																																								
E	2008	ALL	Body	Lift Gate Module																																																								
E	2008	ALL	Body	Memory Seat Module																																																								
E	2008	ALL	Body	Park Assist Module																																																								
E	2008	ALL	Body	Passenger Door Switch																																																								
E	2008	ALL	Body	Passenger Presence System																																																								
E	2008	ALL	Body	Radio																																																								
E	2008	ALL	Body	Rear HVAC/RSA																																																								
E	2008	ALL	Body	Rear Seat Module																																																								
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
E	2008	ALL	Body	Rollover Sensor																																																								
E	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
E	2008	ALL	Body	Theft Deterrent Module																																																								
E	2008	ALL	Body	TV Antenna Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																								
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																								
E	2009	ALL	Chassis	Electronic Brake Control Module																																																								
E	2009	ALL	Chassis	Electronic Suspension Control																																																								
E	2009	ALL	Body	Amplifier (Bose)																																																								
E	2009	ALL	Body	Body Control Module																																																								
E	2009	ALL	Body	Body Control Module (aux.)																																																								
E	2009	ALL	Body	Digital Radio Receiver																																																								
E	2009	ALL	Body	Driver Door Switch																																																								
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																								
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																								
E	2009	ALL	Body	HVAC Control Module																																																								
E	2009	ALL	Body	Instrument Panel Cluster																																																								
E	2009	ALL	Body	Lift Gate Module																																																								
E	2009	ALL	Body	Memory Seat Module																																																								
E	2009	ALL	Body	Park Assist Module																																																								
E	2009	ALL	Body	Passenger Door Switch																																																								
E	2009	ALL	Body	Passenger Presence System																																																								
E	2009	ALL	Body	Radio																																																								
E	2009	ALL	Body	Rear HVAC/RSA																																																								
E	2009	ALL	Body	Rear Seat Module																																																								
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																								
E	2009	ALL	Body	Rollover Sensor																																																								
E	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
E	2009	ALL	Body	Theft Deterrent Module																																																								
E	2009	ALL	Body	TV Antenna Module																																																								
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																				
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																								
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																								
K	2004	ALL	Chassis	ESC																																																								
K	2004	ALL	Chassis	Rear Wheel Steering																																																								
K	2004	ALL	Chassis	Tire Pressure Monitor																																															V									
K	2004	ALL	Chassis	VSES																																																								
K	2004	ALL	Body	Amplifier (Bose)																							V																																	
K	2004	ALL	Body	Body Control Module																																																								
K	2004	ALL	Body	CD Changer																																																								
K	2004	ALL	Body	Chime																																																								
K	2004	ALL	Body	Driver Door Module																																																								
K	2004	ALL	Body	Driver Seat Module																								V																								V								
K	2004	ALL	Body	Heating and Air Conditioning Auto																								V																									V	V						
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																								V																									V	V						
K	2004	ALL	Body	Heating and Air Conditioning Manual																								V																									V	V						
K	2004	ALL	Body	Instrument Panel Cluster																V	V							V																																
K	2004	ALL	Body	OnStar																																																							
K	2004	ALL	Body	Passenger Door Module																																																			V	V			
K	2004	ALL	Body	Passenger Presence System																																																					V		
K	2004	ALL	Body	Base Radio																																																							

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2004	ALL	Body	Uplevel Radio																																																								
K	2004	ALL	Body	Navigation Radio																																																								
K	2004	ALL	Body	Rear Aux. Climate Module																								V																											V					V
K	2004	ALL	Body	Rear HVAC																																																								
K	2004	ALL	Body	Rear Seat Audio																																																								
K	2004	ALL	Body	Rear Seat Entertainment																																																								
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																				
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																								
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																								
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																								
K	2005	ALL	Chassis	ESC																																																								
K	2005	ALL	Chassis	Rear Wheel Steering																																																								
K	2005	ALL	Chassis	Tire Pressure Monitor																																																	V							
K	2005	ALL	Chassis	VSES																																																								
K	2005	ALL	Body	Amplifier (Bose)																							V																																	
K	2005	ALL	Body	Body Control Module																																																								
K	2005	ALL	Body	CD Changer																																																								
K	2005	ALL	Body	Chime																																																								
K	2005	ALL	Body	Disc Player and Video Display																																																								
K	2005	ALL	Body	Driver Door Module																																																								
K	2005	ALL	Body	Driver Seat Module																								V																										V						
K	2005	ALL	Body	Generator Battery Control Module																																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto																								V																											V	V				
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																								V																											V	V				
K	2005	ALL	Body	Heating and Air Conditioning Manual																								V																											V	V				
K	2005	ALL	Body	Instrument Panel Cluster																V	V							V																																
K	2005	ALL	Body	Passenger Door Module																																																					V	V		
K	2005	ALL	Body	Passenger Presence System																																																								V
K	2005	ALL	Body	Base Radio																																																								
K	2005	ALL	Body	Uplevel Radio																																																								
K	2005	ALL	Body	Navigation Radio																																																								
K	2005	ALL	Body	Rear Aux. Climate Module																								V																											V					V
K	2005	ALL	Body	Rear HVAC																																																								
K	2005	ALL	Body	Rear Seat Audio																																																								
K	2005	ALL	Body	Remote Function Actuation																																																								
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																				
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																								
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																								
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																								
K	2006	ALL	Chassis	ESC																																																								
K	2006	ALL	Chassis	Tire Pressure Monitor																																																	V							
K	2006	ALL	Chassis	VSES																																																								
K	2006	ALL	Body	Amplifier (Bose)																							V																																	
K	2006	ALL	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2006	ALL	Body	CD Changer																																																								
K	2006	ALL	Body	Chime																																																								
K	2006	ALL	Body	Disc Player and Video Display																																																								
K	2006	ALL	Body	Driver Door Module																																																								
K	2006	ALL	Body	Driver Seat Module																								V																										V						
K	2006	ALL	Body	Generator Battery Control Module																																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto																								V																											V	V				
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																								V																											V	V				
K	2006	ALL	Body	Heating and Air Conditioning Manual																								V																											V	V				
K	2006	ALL	Body	Instrument Panel Cluster																V	V							V																																
K	2006	ALL	Body	Passenger Door Module																																																					V	V		
K	2006	ALL	Body	Passenger Presence System																																																								V
K	2006	ALL	Body	Base Radio																																																								
K	2006	ALL	Body	Uplevel Radio																																																								
K	2006	ALL	Body	Navigation Radio																																																								
K	2006	ALL	Body	Rear Aux. Climate Module																								V																											V					V
K	2006	ALL	Body	Rear HVAC																																																								
K	2006	ALL	Body	Rear Seat Audio																																																								
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module				V						V																																														
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
K	2007	ALL	Chassis	Electronic Brake Control Module																																																								
K	2007	ALL	Chassis	Electronic Suspension Control																																																								
K	2007	ALL	Body	Amplifier (Bose)																																																								
K	2007	ALL	Body	Assist Step Controller																																																								
K	2007	ALL	Body	Body Control Module																																																								
K	2007	ALL	Body	Body Control Module (aux.)																																																								
K	2007	ALL	Body	Digital Radio Receiver																																																								
K	2007	ALL	Body	Driver Door Switch																																																								
K	2007	ALL	Body	HVAC Control Module																																																								
K	2007	ALL	Body	Inside Rear View Mirror Module																																																								
K	2007	ALL	Body	Instrument Panel Cluster																																																								
K	2007	ALL	Body	Lift Gate Module																																																								
K	2007	ALL	Body	Memory Seat Module																																																								
K	2007	ALL	Body	Park Assist Module																																																								
K	2007	ALL	Body	Passenger Door Switch																																																								
K	2007	ALL	Body	Passenger Presence System																																																								
K	2007	ALL	Body	Radio																																																								
K	2007	ALL	Body	Rear Heated Seat Module																																																								
K	2007	ALL	Body	Rear HVAC/RSA																																																								
K	2007	ALL	Body	Rollover Sensor																																																								
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2007	ALL	Body	Theft Deterrent Module																																																								
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module										V																																														
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
K	2008	ALL	Chassis	Electronic Brake Control Module																																																								
K	2008	ALL	Chassis	Electronic Suspension Control																																																								
K	2008	ALL	Chassis	Trailer Brake Control Module																																																								
K	2008	ALL	Body	Amplifier (Bose)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2008	ALL	Body	Assist Step Controller																																																								
K	2008	ALL	Body	Body Control Module																																																								
K	2008	ALL	Body	Body Control Module (aux.)																																																								
K	2008	ALL	Body	Digital Radio Receiver																																																								
K	2008	ALL	Body	Driver Door Switch																																																								
K	2008	ALL	Body	HVAC Control Module																																																								
K	2008	ALL	Body	Inside Rear View Mirror Module																																																								
K	2008	ALL	Body	Instrument Panel Cluster																																																								
K	2008	ALL	Body	Lift Gate Module																																																								
K	2008	ALL	Body	Memory Seat Module																																																								
K	2008	ALL	Body	Park Assist Module																																																								
K	2008	ALL	Body	Passenger Door Switch																																																								
K	2008	ALL	Body	Passenger Presence System																																																								
K	2008	ALL	Body	Radio																																																								
K	2008	ALL	Body	Rear Heated Seat Module																																																								
K	2008	ALL	Body	Rear HVAC/RSA																																																								
K	2008	ALL	Body	Rollover Sensor																																																								
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2008	ALL	Body	Theft Deterrent Module																																																								
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2009	ALL	Chassis	Electronic Brake Control Module																																																								
K	2009	ALL	Chassis	Electronic Suspension Control																																																								
K	2009	ALL	Chassis	Trailer Brake Control Module																																																								
K	2009	ALL	Body	Amplifier (Bose)																																																								
K	2009	ALL	Body	Assist Step Controller																																																								
K	2009	ALL	Body	Body Control Module																																																								
K	2009	ALL	Body	Body Control Module (aux.)																																																								
K	2009	ALL	Body	Digital Radio Receiver																																																								
K	2009	ALL	Body	Driver Door Switch																																																								
K	2009	ALL	Body	HVAC Control Module																																																								
K	2009	ALL	Body	Inside Rear View Mirror Module																																																								
K	2009	ALL	Body	Instrument Panel Cluster																																																								
K	2009	ALL	Body	Left Side Object Detection Module																																																								
K	2009	ALL	Body	Lift Gate Module																																																								
K	2009	ALL	Body	Memory Seat Module																																																								
K	2009	ALL	Body	Park Assist Module																																																								
K	2009	ALL	Body	Passenger Door Switch																																																								
K	2009	ALL	Body	Passenger Presence System																																																								
K	2009	ALL	Body	Radio																																																								
K	2009	ALL	Body	Rear Heated Seat Module																																																								
K	2009	ALL	Body	Rear HVAC/RSA																																																								
K	2009	ALL	Body	Right Side Object Detection Module																																																								
K	2009	ALL	Body	Rollover Sensor																																																								
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2009	ALL	Body	Theft Deterrent Module																																																								
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																														
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2010	ALL	Chassis	Electronic Brake Control Module																																																								
K	2010	ALL	Chassis	Electronic Suspension Control																																																								
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	ALL	Body	Amplifier (Bose)																																																								
K	2010	ALL	Body	Assist Step Controller																																																								
K	2010	ALL	Body	Body Control Module																																																								
K	2010	ALL	Body	Body Control Module (aux.)																																																								
K	2010	ALL	Body	Digital Radio Receiver																																																								
K	2010	ALL	Body	Driver Door Switch																																																								
K	2010	ALL	Body	HVAC Control Module																																																								
K	2010	ALL	Body	Inside Rear View Mirror Module																																																								
K	2010	ALL	Body	Instrument Panel Cluster																																																								
K	2010	ALL	Body	Left Side Object Detection Module																																																								
K	2010	ALL	Body	Lift Gate Module																																																								
K	2010	ALL	Body	Memory Seat Module																																																								
K	2010	ALL	Body	Park Assist Module																																																								
K	2010	ALL	Body	Passenger Door Switch																																																								
K	2010	ALL	Body	Passenger Presence System																																																								
K	2010	ALL	Body	Radio																																																								
K	2010	ALL	Body	Rear Heated Seat Module																																																								
K	2010	ALL	Body	Rear HVAC/RSA																																																								
K	2010	ALL	Body	Right Side Object Detection Module																																																								
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2010	ALL	Body	Theft Deterrent Module																																																								
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																								
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																								
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																								
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																								
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																								
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																								
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																								
N	2010	SRX	Chassis	Electronic Brake Control Module																																																								
N	2010	SRX	Chassis	Parking Brake Control Module																																																								
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																								
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																																								
N	2010	SRX	Chassis	Suspension Control Module																																																								
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
N	2010	SRX	Body	Passenger Presence Module																																																								
N	2010	SRX	Body	Instrument Cluster																																																								
N	2010	SRX	Body	Headlamp Control Module																																																								
N	2010	SRX	Body	Trailer Interface Control Module																																																								
N	2010	SRX	Body	Radio																																																								
N	2010	SRX	Body	Rear Audio Control Module																																																								
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																								
N	2010	SRX	Body	Multimedia Player Interface Module																																																								
N	2010	SRX	Body	Mobile Telephone Control Module																																																								
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																								
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																								
N	2010	SRX	Body	Liftgate Control Module																																																								
N	2010	SRX	Body	Seat Memory Control Module																																																								
N	2010	SRX	Body	Front Seat Heating Control Module																																																								
N	2010	SRX	Body	Rear Seat Heating Control Module																																																								
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																								
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																								
N	2010	SRX	Body	Parking Assist Control Module																																																								
N	2010	SRX	Body	Steering Column Lock Control Module																																																								
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																								
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																								
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																								
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																								
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																								
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																								
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																								
N	2011	SRX	Chassis	Electronic Brake Control Module																																																								
N	2011	SRX	Chassis	Parking Brake Control Module																																																								
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																								
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																								
N	2011	SRX	Chassis	Suspension Control Module																																																								
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
N	2011	SRX	Body	Passenger Presence Module																																																								
N	2011	SRX	Body	Instrument Cluster																																																								
N	2011	SRX	Body	Headlamp Control Module																																																								
N	2011	SRX	Body	Trailer Interface Control Module																																																								
N	2011	SRX	Body	Radio																																																								
N	2011	SRX	Body	Rear Audio Control Module																																																								
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																								
N	2011	SRX	Body	Multimedia Player Interface Module																																																								
N	2011	SRX	Body	Mobile Telephone Control Module																																																								
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																								
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																								
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																								
N	2011	SRX	Body	Liftgate Control Module																																																								
N	2011	SRX	Body	Seat Memory Control Module																																																								
N	2011	SRX	Body	Front Seat Heating Control Module																																																								
N	2011	SRX	Body	Rear Seat Heating Control Module																																																								
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																								
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																								
N	2011	SRX	Body	Parking Assist Control Module																																																								
N	2011	SRX	Body	Steering Column Lock Control Module																																																								
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																								
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																									
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2012	SRX	Chassis	Electronic Brake Control Module																																																									
N	2012	SRX	Chassis	Parking Brake Control Module																																																									
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2012	SRX	Chassis	Suspension Control Module																																																									
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2012	SRX	Body	Passenger Presence Module																																																									
N	2012	SRX	Body	Instrument Cluster																																																									
N	2012	SRX	Body	Headlamp Control Module																																																									
N	2012	SRX	Body	Trailer Interface Control Module																																																									
N	2012	SRX	Body	Radio																																																									
N	2012	SRX	Body	Rear Audio Control Module																																																									
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																									
N	2012	SRX	Body	Multimedia Player Interface Module																																																									
N	2012	SRX	Body	Mobile Telephone Control Module																																																									
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																																									
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																																									
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																									
N	2012	SRX	Body	Liftgate Control Module																																																									
N	2012	SRX	Body	Seat Memory Control Module																																																									
N	2012	SRX	Body	Front Seat Heating Control Module																																																									
N	2012	SRX	Body	Rear Seat Heating Control Module																																																									
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																									
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																									
N	2012	SRX	Body	Parking Assist Control Module																																																									
N	2012	SRX	Body	Steering Column Lock Control Module																																																									
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																									
N	2013	SRX	Chassis	Electronic Brake Control Module																																																									
N	2013	SRX	Chassis	Parking Brake Control Module																																																									
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																									
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																																									
N	2013	SRX	Chassis	Suspension Control Module																																																									
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																									
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																									
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
N	2013	SRX	Body	Passenger Presence Module																																																									
N	2013	SRX	Body	Instrument Cluster																																																									
N	2013	SRX	Body	Radio/HVAC Control																																																									
N	2013	SRX	Body	Active Safety Control Module																																																									
N	2013	SRX	Body	Headlamp Control Module																																																									
N	2013	SRX	Body	Trailer Interface Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
N	2013	SRX	Body	Radio																																																								
N	2013	SRX	Body	Amplifier																																																								
N	2013	SRX	Body	Media Disc Player																																																								
N	2013	SRX	Body	Human Machine Interface Control Module																																																								
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																																								
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																																								
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																								
N	2013	SRX	Body	Liftgate Control Module																																																								
N	2013	SRX	Body	Seat Memory Control Module																																																								
N	2013	SRX	Body	Rear Seat Heating Control Module																																																								
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																								
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																								
N	2013	SRX	Body	Right Side Object Detection Control Module																																																								
N	2013	SRX	Body	Left Side Object Detection Control Module																																																								
N	2013	SRX	Body	Parking Assist Control Module																																																								
N	2013	SRX	Body	Frontview Camera Module																																																								
N	2013	SRX	Body	Steering Column Lock Control Module																																																								
N	2013	SRX	Body	Long Range Radar Sensor Module																																																								
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																								
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																								
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																								
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																								
N	2014	SRX	Chassis	Electronic Brake Control Module																																																								
N	2014	SRX	Chassis	Parking Brake Control Module																																																								
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																								
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																																								
N	2014	SRX	Chassis	Suspension Control Module																																																								
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
N	2014	SRX	Body	Passenger Presence Module																																																								
N	2014	SRX	Body	Instrument Cluster																																																								
N	2014	SRX	Body	Radio/HVAC Control																																																								
N	2014	SRX	Body	Active Safety Control Module																																																								
N	2014	SRX	Body	Headlamp Control Module																																																								
N	2014	SRX	Body	Trailer Interface Control Module																																																								
N	2014	SRX	Body	Radio																																																								
N	2014	SRX	Body	Amplifier																																																								
N	2014	SRX	Body	Media Disc Player																																																								
N	2014	SRX	Body	Human Machine Interface Control Module																																																								
N	2014	SRX	Body	Navigation Control Module																																																								
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																								
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																																								
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																								
N	2014	SRX	Body	Liftgate Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																									
N	2014	SRX	Body	Rear Seat Heating Control Module																																																										
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2014	SRX	Body	Right Side Object Detection Control Module																																																										
N	2014	SRX	Body	Left Side Object Detection Control Module																																																										
N	2014	SRX	Body	Parking Assist Control Module																																																										
N	2014	SRX	Body	Frontview Camera Module																																																										
N	2014	SRX	Body	Steering Column Lock Control Module																																																										
N	2014	SRX	Body	Long Range Radar Sensor Module																																																										
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																										
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2015	SRX	Chassis	Electronic Brake Control Module																																																										
N	2015	SRX	Chassis	Parking Brake Control Module																																																										
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2015	SRX	Chassis	Suspension Control Module																																																										
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2015	SRX	Body	Passenger Presence Module																																																										
N	2015	SRX	Body	Instrument Cluster																																																										
N	2015	SRX	Body	Radio/HVAC Control																																																										
N	2015	SRX	Body	Active Safety Control Module																																																										
N	2015	SRX	Body	Headlamp Control Module																																																										
N	2015	SRX	Body	Trailer Interface Control Module																																																										
N	2015	SRX	Body	Radio																																																										
N	2015	SRX	Body	Amplifier																																																										
N	2015	SRX	Body	Rear Audio Control Module																																																										
N	2015	SRX	Body	Media Disc Player																																																										
N	2015	SRX	Body	Human Machine Interface Control Module																																																										
N	2015	SRX	Body	Navigation Control Module																																																										
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																										
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2015	SRX	Body	Liftgate Control Module																																																										
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2015	SRX	Body	Rear Seat Heating Control Module																																																										
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2015	SRX	Body	Right Side Object Detection Control Module																																																										
N	2015	SRX	Body	Left Side Object Detection Control Module																																																										
N	2015	SRX	Body	Parking Assist Control Module																																																										
N	2015	SRX	Body	Frontview Camera Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
N	2015	SRX	Body	Steering Column Lock Control Module																																																									
N	2015	SRX	Body	Long Range Radar Sensor Module																																																										
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																										
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2016	SRX	Chassis	Electronic Brake Control Module																																																										
N	2016	SRX	Chassis	Parking Brake Control Module																																																										
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2016	SRX	Chassis	Suspension Control Module																																																										
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2016	SRX	Body	Passenger Presence Module																																																										
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																										
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																																										
N	2016	SRX	Body	Radio/HVAC Control																																																										
N	2016	SRX	Body	Active Safety Control Module																																																										
N	2016	SRX	Body	Headlamp Control Module																																																										
N	2016	SRX	Body	Trailer Interface Control Module																																																										
N	2016	SRX	Body	Radio																																																										
N	2016	SRX	Body	Amplifier																																																										
N	2016	SRX	Body	Rear Audio Control Module																																																										
N	2016	SRX	Body	Media Disc Player																																																										
N	2016	SRX	Body	Human Machine Interface Control Module																																																										
N	2016	SRX	Body	Navigation Control Module																																																										
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																										
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2016	SRX	Body	Liftgate Control Module																																																V										
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																										
N	2016	SRX	Body	Rear Seat Heating Control Module																																																										
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2016	SRX	Body	Right Side Object Detection Control Module																																																										
N	2016	SRX	Body	Left Side Object Detection Control Module																																																										
N	2016	SRX	Body	Parking Assist Control Module																																																										
N	2016	SRX	Body	Frontview Camera Module																																																										
N	2016	SRX	Body	Steering Column Lock Control Module																																																										
N	2016	SRX	Body	Long Range Radar Sensor Module																																																										
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																										
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																															
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
3	2011	ALL	Chassis	Electronic Brake Control Module																																																									
3	2011	ALL	Chassis	Electronic Suspension Control																																																									
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																									
3	2011	ALL	Body	Amplifier (Bose)																																																									
3	2011	ALL	Body	Assist Step Controller																																																									
3	2011	ALL	Body	Body Control Module																																																									
3	2011	ALL	Body	Body Control Module (aux.)																																																									
3	2011	ALL	Body	Digital Radio Receiver																																																									
3	2011	ALL	Body	Driver Door Switch																																																									
3	2011	ALL	Body	HVAC Control Module																																																									
3	2011	ALL	Body	Inside Rear View Mirror Module																																																									
3	2011	ALL	Body	Instrument Panel Cluster																																																									
3	2011	ALL	Body	Left Side Object Detection Module																																																									
3	2011	ALL	Body	Lift Gate Module																																																									
3	2011	ALL	Body	Memory Seat Module																																																									
3	2011	ALL	Body	Park Assist Module																																																									
3	2011	ALL	Body	Passenger Door Switch																																																									
3	2011	ALL	Body	Passenger Presence System																																																									
3	2011	ALL	Body	Radio																																																									
3	2011	ALL	Body	Rear Heated Seat Module																																																									
3	2011	ALL	Body	Rear HVAC/RSA																																																									
3	2011	ALL	Body	Right Side Object Detection Module																																																									
3	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
3	2011	ALL	Body	Theft Deterrent Module																																																									
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																															
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
3	2012	ALL	Chassis	Electronic Brake Control Module																																																									
3	2012	ALL	Chassis	Electronic Suspension Control																																																									
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																									
3	2012	ALL	Body	Amplifier (Bose)																																																									
3	2012	ALL	Body	Assist Step Controller																																																									
3	2012	ALL	Body	Body Control Module																																																									
3	2012	ALL	Body	Body Control Module (aux.)																																																									
3	2012	ALL	Body	Driver Door Switch																																																									
3	2012	ALL	Body	HVAC Control Module																																																									
3	2012	ALL	Body	Inside Rear View Mirror Module																																																									
3	2012	ALL	Body	Instrument Panel Cluster																																																									
3	2012	ALL	Body	Left Side Object Detection Module																																																									
3	2012	ALL	Body	Lift Gate Module																																																									
3	2012	ALL	Body	Memory Seat Module																																																									
3	2012	ALL	Body	Park Assist Module																																																									
3	2012	ALL	Body	Passenger Door Switch																																																									
3	2012	ALL	Body	Passenger Presence System																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
3	2012	ALL	Body	Radio																																																								
3	2012	ALL	Body	Rear Heated Seat Module																																																								
3	2012	ALL	Body	Rear HVAC/RSA																																																								
3	2012	ALL	Body	Right Side Object Detection Module																																																								
3	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
3	2012	ALL	Body	Theft Deterrent Module																																																								
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																														
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
3	2013	ALL	Chassis	Electronic Brake Control Module																																																								
3	2013	ALL	Chassis	Electronic Suspension Control																																																								
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																								
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																								
3	2013	ALL	Body	Amplifier (Bose)																																																								
3	2013	ALL	Body	Assist Step Controller																																																								
3	2013	ALL	Body	Body Control Module																																																								
3	2013	ALL	Body	Body Control Module (aux.)																																																								
3	2013	ALL	Body	Driver Door Switch																																																								
3	2013	ALL	Body	HVAC Control Module																																																								
3	2013	ALL	Body	Inside Rear View Mirror Module																																																								
3	2013	ALL	Body	Instrument Panel Cluster																																																								
3	2013	ALL	Body	Left Side Object Detection Module																																																								
3	2013	ALL	Body	Lift Gate Module																																																								
3	2013	ALL	Body	Memory Seat Module																																																								
3	2013	ALL	Body	Park Assist Module																																																								
3	2013	ALL	Body	Passenger Door Switch																																																								
3	2013	ALL	Body	Passenger Presence System																																																								
3	2013	ALL	Body	Radio																																																								
3	2013	ALL	Body	Rear Heated Seat Module																																																								
3	2013	ALL	Body	Rear HVAC/RSA																																																								
3	2013	ALL	Body	Right Side Object Detection Module																																																								
3	2013	ALL	Body	Supplemental Inflatable Restraint																																																								
3	2013	ALL	Body	Theft Deterrent Module																																																								
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																								
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																								
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																								
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																								
3	2014	Escalade	Chassis	Suspension Control Module																																																								
3	2014	Escalade	Body	Body Control Module																																																								
3	2014	Escalade	Body	Auxiliary Body Control Module																																																								
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
3	2014	Escalade	Body	Passenger Presence Module																																																								
3	2014	Escalade	Body	Instrument Cluster																																																								
3	2014	Escalade	Body	Radio																																																								
3	2014	Escalade	Body	Amplifier																																																								
3	2014	Escalade	Body	Rear Audio Control Module																																																								
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																								
3	2014	Escalade	Body	Personal Audio Link Control Module																																																V								
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																								
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
3	2014	Escalade	Body	HVAC Control Module																																																								
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																								
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																								
3	2014	Escalade	Body	Liftgate Control Module																																																								
3	2014	Escalade	Body	Seat Memory Control Module																																																								
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																								
3	2014	Escalade	Body	Assist Step Control Module																																																								
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																								
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																								
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																								
3	2014	Escalade	Body	Parking Assist Control Module																																																								
3	2014	Escalade	Body	Theft Deterrent Module																																																								
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																								
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																								
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																								
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																								
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																								
3	2014	Escalade ESV	Body	Body Control Module																																																								
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																								
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
3	2014	Escalade ESV	Body	Passenger Presence Module																																																								
3	2014	Escalade ESV	Body	Instrument Cluster																																																								
3	2014	Escalade ESV	Body	Radio																																																								
3	2014	Escalade ESV	Body	Amplifier																																																								
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																								
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																								
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																								
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																								
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																								
3	2014	Escalade ESV	Body	HVAC Control Module																																																								
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																								
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																								
3	2014	Escalade ESV	Body	Liftgate Control Module																																																								
3	2014	Escalade ESV	Body	Seat Memory Control Module																																																								
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																								
3	2014	Escalade ESV	Body	Assist Step Control Module																																																								
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																								
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																								
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																								
3	2014	Escalade ESV	Body	Parking Assist Control Module																																																								
3	2014	Escalade ESV	Body	Theft Deterrent Module																																																								
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																								
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																								
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																								
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																								
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																								
3	2015	Escalade	Chassis	Electronic Brake Control Module																																																								
3	2015	Escalade	Chassis	Parking Brake Control Module																																																								
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																								
3	2015	Escalade	Chassis	Power Steering Control Module																																																								
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																								
3	2015	Escalade	Chassis	Suspension Control Module																																																								
3	2015	Escalade	Body	Body Control Module																																																								
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
3	2015	Escalade	Body	Passenger Presence Module																																																								
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																								
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																								
3	2015	Escalade	Body	Instrument Cluster																																																								
3	2015	Escalade	Body	Radio/HVAC Control																																																								
3	2015	Escalade	Body	Active Safety Control Module																																																								
3	2015	Escalade	Body	Video Processing Control Module																																																								
3	2015	Escalade	Body	Radio																																																								
3	2015	Escalade	Body	Amplifier																																																								
3	2015	Escalade	Body	Media Disc Player																																																								
3	2015	Escalade	Body	Human Machine Interface Control Module																																																								
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																								
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																								
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																								
3	2015	Escalade	Body	HVAC Control Module																																																								
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																								
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																								
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																								
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																								
3	2015	Escalade	Body	Keyless Entry Control Module																																																								
3	2015	Escalade	Body	Assist Step Control Module																																																								
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																								
3	2015	Escalade	Body	Parking Assist Control Module																																																								
3	2015	Escalade	Body	Frontview Camera Module																																																								
3	2015	Escalade	Body	Steering Column Lock Control Module																																																								
3	2015	Escalade	Body	Battery Energy Control Module																																																								
3	2015	Escalade	Body	Long Range Radar Sensor Module																																																								
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																								
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																								
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																								
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																								
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																								
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																								
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																									
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																									
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																									
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																																									
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																									
3	2015	Escalade ESV	Chassis	Suspension Control Module																																																									
3	2015	Escalade ESV	Body	Body Control Module																																																									
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
3	2015	Escalade ESV	Body	Passenger Presence Module																																																									
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																									
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																									
3	2015	Escalade ESV	Body	Instrument Cluster																																																									
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																									
3	2015	Escalade ESV	Body	Active Safety Control Module																																																									
3	2015	Escalade ESV	Body	Video Processing Control Module																																																									
3	2015	Escalade ESV	Body	Radio																																																									
3	2015	Escalade ESV	Body	Amplifier																																																									
3	2015	Escalade ESV	Body	Media Disc Player																																																									
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																									
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																									
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																									
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																									
3	2015	Escalade ESV	Body	HVAC Control Module																																																									
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																V									
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																									
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																									
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																									
3	2015	Escalade ESV	Body	Assist Step Control Module																																																									
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																									
3	2015	Escalade ESV	Body	Parking Assist Control Module																																																									
3	2015	Escalade ESV	Body	Frontview Camera Module																																																									
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																									
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																									
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																									
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																									
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																									
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																									
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
3	2016	Escalade	Chassis	Electronic Brake Control Module																																																									
3	2016	Escalade	Chassis	Parking Brake Control Module																																																									
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																									
3	2016	Escalade	Chassis	Power Steering Control Module																																																									
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																									
3	2016	Escalade	Chassis	Suspension Control Module																																																									
3	2016	Escalade	Body	Body Control Module																																																									
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
3	2016	Escalade	Body	Passenger Presence Module																																																								
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																								
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																								
3	2016	Escalade	Body	Instrument Cluster																																																								
3	2016	Escalade	Body	Radio/HVAC Control																																																								
3	2016	Escalade	Body	Active Safety Control Module																																																								
3	2016	Escalade	Body	Video Processing Control Module																																																								
3	2016	Escalade	Body	Radio																																																								
3	2016	Escalade	Body	Amplifier																																																								
3	2016	Escalade	Body	Media Disc Player																																																								
3	2016	Escalade	Body	Human Machine Interface Control Module																																																								
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																																								
3	2016	Escalade	Body	HVAC Control Module																																																								
3	2016	Escalade	Body	Liftgate Control Module																																																V								
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																								
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																								
3	2016	Escalade	Body	Keyless Entry Control Module																																																								
3	2016	Escalade	Body	Assist Step Control Module																																																								
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																								
3	2016	Escalade	Body	Parking Assist Control Module																																																								
3	2016	Escalade	Body	Frontview Camera Module																																																								
3	2016	Escalade	Body	Steering Column Lock Control Module																																																								
3	2016	Escalade	Body	Long Range Radar Sensor Module																																																								
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																								
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																								
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																								
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																								
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																								
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																								
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																								
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																																								
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																								
3	2016	Escalade ESV	Chassis	Suspension Control Module																																																								
3	2016	Escalade ESV	Body	Body Control Module																																																								
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
3	2016	Escalade ESV	Body	Passenger Presence Module																																																								
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																								
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																								
3	2016	Escalade ESV	Body	Instrument Cluster																																																								
3	2016	Escalade ESV	Body	Radio Control																																																								
3	2016	Escalade ESV	Body	HVAC Control																																																								
3	2016	Escalade ESV	Body	Active Safety Control Module																																																								
3	2016	Escalade ESV	Body	Video Processing Control Module																																																								
3	2016	Escalade ESV	Body	Radio																																																								
3	2016	Escalade ESV	Body	Amplifier																																																								
3	2016	Escalade ESV	Body	Media Disc Player																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																									
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																									
3	2016	Escalade ESV	Body	HVAC Control Module																																																										
3	2016	Escalade ESV	Body	Liftgate Control Module																																																V									
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																									
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																									
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																									
3	2016	Escalade ESV	Body	Assist Step Control Module																																																									
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																									
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																									
3	2016	Escalade ESV	Body	Frontview Camera Module																																																									
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																									
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																									
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																									
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																									
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																									
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																									
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																															
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
4	2011	ALL	Chassis	Electronic Brake Control Module																																																									
4	2011	ALL	Chassis	Electronic Suspension Control																																																									
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																									
4	2011	ALL	Body	Amplifier (Bose)																																																									
4	2011	ALL	Body	Assist Step Controller																																																									
4	2011	ALL	Body	Body Control Module																																																									
4	2011	ALL	Body	Body Control Module (aux.)																																																									
4	2011	ALL	Body	Driver Door Switch																																																									
4	2011	ALL	Body	HVAC Control Module																																																									
4	2011	ALL	Body	Inside Rear View Mirror Module																																																									
4	2011	ALL	Body	Instrument Panel Cluster																																																									
4	2011	ALL	Body	Left Side Object Detection Module																																																									
4	2011	ALL	Body	Lift Gate Module																																																									
4	2011	ALL	Body	Memory Seat Module																																																									
4	2011	ALL	Body	Park Assist Module																																																									
4	2011	ALL	Body	Passenger Door Switch																																																									
4	2011	ALL	Body	Passenger Presence System																																																									
4	2011	ALL	Body	Radio																																																									
4	2011	ALL	Body	Rear Heated Seat Module																																																									
4	2011	ALL	Body	Rear HVAC/RSA																																																									
4	2011	ALL	Body	Right Side Object Detection Module																																																									
4	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
4	2011	ALL	Body	Theft Deterrent Module																																																									
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																															
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
4	2012	ALL	Chassis	Electronic Brake Control Module																																																								
4	2012	ALL	Chassis	Electronic Suspension Control																																																								
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																								
4	2012	ALL	Body	Amplifier (Bose)																																																								
4	2012	ALL	Body	Assist Step Controller																																																								
4	2012	ALL	Body	Body Control Module																																																								
4	2012	ALL	Body	Body Control Module (aux.)																																																								
4	2012	ALL	Body	Driver Door Switch																																																								
4	2012	ALL	Body	HVAC Control Module																																																								
4	2012	ALL	Body	Inside Rear View Mirror Module																																																								
4	2012	ALL	Body	Instrument Panel Cluster																																																								
4	2012	ALL	Body	Left Side Object Detection Module																																																								
4	2012	ALL	Body	Lift Gate Module																																																								
4	2012	ALL	Body	Memory Seat Module																																																								
4	2012	ALL	Body	Park Assist Module																																																								
4	2012	ALL	Body	Passenger Door Switch																																																								
4	2012	ALL	Body	Passenger Presence System																																																								
4	2012	ALL	Body	Radio																																																								
4	2012	ALL	Body	Rear Heated Seat Module																																																								
4	2012	ALL	Body	Rear HVAC/RSA																																																								
4	2012	ALL	Body	Right Side Object Detection Module																																																								
4	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
4	2012	ALL	Body	Theft Deterrent Module																																																								
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																														
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
4	2013	ALL	Chassis	Electronic Brake Control Module																																																								
4	2013	ALL	Chassis	Electronic Suspension Control																																																								
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																								
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																								
4	2013	ALL	Body	Amplifier (Bose)																																																								
4	2013	ALL	Body	Assist Step Controller																																																								
4	2013	ALL	Body	Body Control Module																																																								
4	2013	ALL	Body	Body Control Module (aux.)																																																								
4	2013	ALL	Body	Driver Door Switch																																																								
4	2013	ALL	Body	HVAC Control Module																																																								
4	2013	ALL	Body	Inside Rear View Mirror Module																																																								
4	2013	ALL	Body	Instrument Panel Cluster																																																								
4	2013	ALL	Body	Left Side Object Detection Module																																																								
4	2013	ALL	Body	Lift Gate Module																																																								
4	2013	ALL	Body	Memory Seat Module																																																								
4	2013	ALL	Body	Park Assist Module																																																								
4	2013	ALL	Body	Passenger Door Switch																																																								
4	2013	ALL	Body	Passenger Presence System																																																								
4	2013	ALL	Body	Radio																																																								
4	2013	ALL	Body	Rear Heated Seat Module																																																								
4	2013	ALL	Body	Rear HVAC/RSA																																																								
4	2013	ALL	Body	Right Side Object Detection Module																																																								
4	2013	ALL	Body	Supplemental Inflatable Restraint																																																								
4	2013	ALL	Body	Theft Deterrent Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																									
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
4	2014	Escalade	Chassis	Electronic Brake Control Module																																																									
4	2014	Escalade	Chassis	Suspension Control Module																																																									
4	2014	Escalade	Body	Body Control Module																																																									
4	2014	Escalade	Body	Auxiliary Body Control Module																																																									
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
4	2014	Escalade	Body	Passenger Presence Module																																																									
4	2014	Escalade	Body	Instrument Cluster																																																									
4	2014	Escalade	Body	Radio																																																									
4	2014	Escalade	Body	Amplifier																																																									
4	2014	Escalade	Body	Rear Audio Control Module																																																									
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																																									
4	2014	Escalade	Body	Personal Audio Link Control Module																																																V									
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																									
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																									
4	2014	Escalade	Body	HVAC Control Module																																																									
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																									
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																									
4	2014	Escalade	Body	Liftgate Control Module																																																									
4	2014	Escalade	Body	Seat Memory Control Module																																																									
4	2014	Escalade	Body	Rear Seat Heating Control Module																																																									
4	2014	Escalade	Body	Assist Step Control Module																																																									
4	2014	Escalade	Body	Right Side Object Detection Control Module																																																									
4	2014	Escalade	Body	Left Side Object Detection Control Module																																																									
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																																									
4	2014	Escalade	Body	Parking Assist Control Module																																																									
4	2014	Escalade	Body	Theft Deterrent Module																																																									
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																									
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																									
4	2014	Escalade ESV	Chassis	Suspension Control Module																																																									
4	2014	Escalade ESV	Body	Body Control Module																																																									
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																									
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
4	2014	Escalade ESV	Body	Passenger Presence Module																																																									
4	2014	Escalade ESV	Body	Instrument Cluster																																																									
4	2014	Escalade ESV	Body	Radio																																																									
4	2014	Escalade ESV	Body	Amplifier																																																									
4	2014	Escalade ESV	Body	Rear Audio Control Module																																																									
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																									
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																V									
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																									
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																									
4	2014	Escalade ESV	Body	HVAC Control Module																																																									
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																									
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
4	2014	Escalade ESV	Body	Liftgate Control Module																																																								
4	2014	Escalade ESV	Body	Seat Memory Control Module																																																								
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																								
4	2014	Escalade ESV	Body	Assist Step Control Module																																																								
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																								
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																								
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																								
4	2014	Escalade ESV	Body	Parking Assist Control Module																																																								
4	2014	Escalade ESV	Body	Theft Deterrent Module																																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																								
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																								
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																								
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																								
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																								
4	2015	Escalade	Chassis	Electronic Brake Control Module																																																								
4	2015	Escalade	Chassis	Parking Brake Control Module																																																								
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																								
4	2015	Escalade	Chassis	Power Steering Control Module																																																								
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																								
4	2015	Escalade	Chassis	Suspension Control Module																																																								
4	2015	Escalade	Body	Body Control Module																																																								
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
4	2015	Escalade	Body	Passenger Presence Module																																																								
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																								
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																								
4	2015	Escalade	Body	Instrument Cluster																																																								
4	2015	Escalade	Body	Radio/HVAC Control																																																								
4	2015	Escalade	Body	Active Safety Control Module																																																								
4	2015	Escalade	Body	Video Processing Control Module																																																								
4	2015	Escalade	Body	Radio																																																								
4	2015	Escalade	Body	Amplifier																																																								
4	2015	Escalade	Body	Media Disc Player																																																								
4	2015	Escalade	Body	Human Machine Interface Control Module																																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																								
4	2015	Escalade	Body	HVAC Control Module																																																								
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																								
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																								
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																								
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																								
4	2015	Escalade	Body	Keyless Entry Control Module																																																								
4	2015	Escalade	Body	Assist Step Control Module																																																								
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
4	2015	Escalade	Body	Parking Assist Control Module																																																									
4	2015	Escalade	Body	Frontview Camera Module																																																										
4	2015	Escalade	Body	Steering Column Lock Control Module																																																										
4	2015	Escalade	Body	Battery Energy Control Module																																																										
4	2015	Escalade	Body	Long Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																										
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																																										
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2015	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2015	Escalade ESV	Body	Body Control Module																																																										
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2015	Escalade ESV	Body	Passenger Presence Module																																																										
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2015	Escalade ESV	Body	Instrument Cluster																																																										
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																										
4	2015	Escalade ESV	Body	Active Safety Control Module																																																										
4	2015	Escalade ESV	Body	Video Processing Control Module																																																										
4	2015	Escalade ESV	Body	Radio																																																										
4	2015	Escalade ESV	Body	Amplifier																																																										
4	2015	Escalade ESV	Body	Media Disc Player																																																										
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2015	Escalade ESV	Body	HVAC Control Module																																																										
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																V									
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																										
4	2015	Escalade ESV	Body	Assist Step Control Module																																																										
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
4	2015	Escalade ESV	Body	Parking Assist Control Module																																																										
4	2015	Escalade ESV	Body	Frontview Camera Module																																																										
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																								
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																								
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																								
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																								
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																								
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
4	2016	Escalade	Chassis	Electronic Brake Control Module																																																								
4	2016	Escalade	Chassis	Parking Brake Control Module																																																								
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																								
4	2016	Escalade	Chassis	Power Steering Control Module																																																								
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																								
4	2016	Escalade	Chassis	Suspension Control Module																																																								
4	2016	Escalade	Body	Body Control Module																																																								
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
4	2016	Escalade	Body	Passenger Presence Module																																																								
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																								
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																								
4	2016	Escalade	Body	Instrument Cluster																																																								
4	2016	Escalade	Body	Radio/HVAC Control																																																								
4	2016	Escalade	Body	Active Safety Control Module																																																								
4	2016	Escalade	Body	Video Processing Control Module																																																								
4	2016	Escalade	Body	Radio																																																								
4	2016	Escalade	Body	Amplifier																																																								
4	2016	Escalade	Body	Media Disc Player																																																								
4	2016	Escalade	Body	Human Machine Interface Control Module																																																								
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																																								
4	2016	Escalade	Body	HVAC Control Module																																																								
4	2016	Escalade	Body	Liftgate Control Module																																																V								
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																								
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																								
4	2016	Escalade	Body	Keyless Entry Control Module																																																								
4	2016	Escalade	Body	Assist Step Control Module																																																								
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																								
4	2016	Escalade	Body	Parking Assist Control Module																																																								
4	2016	Escalade	Body	Frontview Camera Module																																																								
4	2016	Escalade	Body	Steering Column Lock Control Module																																																								
4	2016	Escalade	Body	Long Range Radar Sensor Module																																																								
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																								
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																								
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																								
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																								
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																									
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																																										
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2016	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2016	Escalade ESV	Body	Body Control Module																																																										
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2016	Escalade ESV	Body	Passenger Presence Module																																																										
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2016	Escalade ESV	Body	Instrument Cluster																																																										
4	2016	Escalade ESV	Body	Radio Control																																																										
4	2016	Escalade ESV	Body	HVAC Control																																																										
4	2016	Escalade ESV	Body	Active Safety Control Module																																																										
4	2016	Escalade ESV	Body	Video Processing Control Module																																																										
4	2016	Escalade ESV	Body	Radio																																																										
4	2016	Escalade ESV	Body	Amplifier																																																										
4	2016	Escalade ESV	Body	Media Disc Player																																																										
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																										
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																										
4	2016	Escalade ESV	Body	HVAC Control Module																																																										
4	2016	Escalade ESV	Body	Liftgate Control Module																																																	V									
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																										
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																										
4	2016	Escalade ESV	Body	Assist Step Control Module																																																										
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
4	2016	Escalade ESV	Body	Parking Assist Control Module																																																										
4	2016	Escalade ESV	Body	Frontview Camera Module																																																										
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																										
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																										
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																										
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																										
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																										
ALL	2004	Hearse	Chassis	DRP/ABS/TCS																																																										
ALL	2004	Hearse	Chassis	Magna Steer																																																										
ALL	2004	Hearse	Chassis	Rear Integration Module																																																										
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																										
ALL	2004	Hearse	Body	Amplifier (Delco)																																																										
ALL	2004	Hearse	Body	Dash Integration Module																																																										
ALL	2004	Hearse	Body	Driver Door Switch																																																										
ALL	2004	Hearse	Body	Driver Door Module																																																										
ALL	2004	Hearse	Body	Passenger Door Module																																																										
ALL	2004	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2004	Hearse	Body	Instrument Panel Module																																																										
ALL	2004	Hearse	Body	Personalization																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
ALL	2004	Hearse	Body	Radio																																																								
ALL	2004	Hearse	Body	Rear Integration Module																																																								
ALL	2004	Hearse	Body	Remote Function Actuation																																																								
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																																																								
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																																								
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																								
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																								
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																								
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																								
ALL	2004	Limousine	Chassis	DRP/ABS/TCS																																																								
ALL	2004	Limousine	Chassis	Magna Steer																																																								
ALL	2004	Limousine	Chassis	Rear Integration Module																																																								
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																								
ALL	2004	Limousine	Body	Amplifier (Delco)																																																								
ALL	2004	Limousine	Body	Dash Integration Module																																																								
ALL	2004	Limousine	Body	Driver Door Switch																																																								
ALL	2004	Limousine	Body	Driver Door Module																																																								
ALL	2004	Limousine	Body	Passenger Door Module																																																								
ALL	2004	Limousine	Body	Left Mid Door Module																																																								
ALL	2004	Limousine	Body	Left Rear Door Module																																																								
ALL	2004	Limousine	Body	Right Mid Door Module																																																								
ALL	2004	Limousine	Body	Right Rear Door Module																																																								
ALL	2004	Limousine	Body	Instrument Panel Cluster																																																								
ALL	2004	Limousine	Body	Instrument Panel Module																																																								
ALL	2004	Limousine	Body	Memory Seat Module																																																								
ALL	2004	Limousine	Body	Navigation Radio																																																								
ALL	2004	Limousine	Body	Personalization																																																								
ALL	2004	Limousine	Body	Radio																																																								
ALL	2004	Limousine	Body	Rear Climate Control Panel																																																								
ALL	2004	Limousine	Body	Rear Integration Module																																																								
ALL	2004	Limousine	Body	Remote Function Actuation																																																								
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																																																								
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																																								
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																								
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																								
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																								
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																								
ALL	2005	Hearse	Chassis	DRP/ABS/TCS																																																								
ALL	2005	Hearse	Chassis	Magna Steer																																																								
ALL	2005	Hearse	Chassis	Rear Integration Module																																																								
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																								
ALL	2005	Hearse	Body	Amplifier (Delco)																																																								
ALL	2005	Hearse	Body	Dash Integration Module																																																								
ALL	2005	Hearse	Body	Driver Door Switch																																																								
ALL	2005	Hearse	Body	Driver Door Module																																																								
ALL	2005	Hearse	Body	Passenger Door Module																																																								
ALL	2005	Hearse	Body	Instrument Panel Cluster																																																								
ALL	2005	Hearse	Body	Instrument Panel Module																																																								
ALL	2005	Hearse	Body	Personalization																																																								
ALL	2005	Hearse	Body	Radio																																																								
ALL	2005	Hearse	Body	Rear Integration Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
ALL	2005	Hearse	Body	Remote Function Actuation																																																								
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																																									
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																																									
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																									
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																									
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																									
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																									
ALL	2005	Limousine	Chassis	DRP/ABS/TCS																																																									
ALL	2005	Limousine	Chassis	Magna Steer																																																									
ALL	2005	Limousine	Chassis	Rear Integration Module																																																									
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																									
ALL	2005	Limousine	Body	Amplifier (Delco)																																																									
ALL	2005	Limousine	Body	Dash Integration Module																																																									
ALL	2005	Limousine	Body	Driver Door Switch																																																									
ALL	2005	Limousine	Body	Driver Door Module																																																									
ALL	2005	Limousine	Body	Passenger Door Module																																																									
ALL	2005	Limousine	Body	Left Mid Door Module																																																									
ALL	2005	Limousine	Body	Left Rear Door Module																																																									
ALL	2005	Limousine	Body	Right Mid Door Module																																																									
ALL	2005	Limousine	Body	Right Rear Door Module																																																									
ALL	2005	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2005	Limousine	Body	Instrument Panel Module																																																									
ALL	2005	Limousine	Body	Memory Seat Module																																																									
ALL	2005	Limousine	Body	Navigation Radio																																																									
ALL	2005	Limousine	Body	Personalization																																																									
ALL	2005	Limousine	Body	Radio																																																									
ALL	2005	Limousine	Body	Rear Climate Control Panel																																																									
ALL	2005	Limousine	Body	Rear Integration Module																																																									
ALL	2005	Limousine	Body	Remote Function Actuation																																																									
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint																																																									
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																																									
ALL	2006	Hearse	Powertrain	Engine Control Module																																																									
ALL	2006	Hearse	Powertrain	Transmission Control Module																																																									
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																																									
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																									
ALL	2006	Hearse	Body	Amplifier (Bose)																																																									
ALL	2006	Hearse	Body	Body Control Module																																																									
ALL	2006	Hearse	Body	Digital Radio Receiver																																																									
ALL	2006	Hearse	Body	Driver Door Switch																																																									
ALL	2006	Hearse	Body	Driver Position Module																																																									
ALL	2006	Hearse	Body	HVAC Control Module																																																									
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																									
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																									
ALL	2006	Hearse	Body	Passenger Door Switch																																																									
ALL	2006	Hearse	Body	Passenger Presence System																																																									
ALL	2006	Hearse	Body	Radio																																																									
ALL	2006	Hearse	Body	Rear Heated Seat Module																																																									
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																									
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																																									
ALL	2006	Hearse	Body	Theft Deterrent Module																																																									
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
ALL	2006	Limousine	Powertrain	Engine Control Module																																																								
ALL	2006	Limousine	Powertrain	Transmission Control Module																																																								
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																																								
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																								
ALL	2006	Limousine	Body	Amplifier (Bose)																																																								
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																								
ALL	2006	Limousine	Body	Body Control Module																																																								
ALL	2006	Limousine	Body	Digital Radio Receiver																																																								
ALL	2006	Limousine	Body	Driver Door Switch																																																								
ALL	2006	Limousine	Body	Driver Position Module																																																								
ALL	2006	Limousine	Body	HVAC Control Module																																																								
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																								
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																								
ALL	2006	Limousine	Body	Passenger Door Switch																																																								
ALL	2006	Limousine	Body	Passenger Presence System																																																								
ALL	2006	Limousine	Body	Radio																																																								
ALL	2006	Limousine	Body	Rear Heated Seat Module																																																								
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																								
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																																								
ALL	2006	Limousine	Body	Theft Deterrent Module																																																								
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																																								
ALL	2007	Hearse	Powertrain	Engine Control Module																																																								
ALL	2007	Hearse	Powertrain	Transmission Control Module																																																								
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																								
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																																								
ALL	2007	Hearse	Body	Amplifier (Bose)																																																								
ALL	2007	Hearse	Body	Body Control Module																																																								
ALL	2007	Hearse	Body	Digital Radio Receiver																																																								
ALL	2007	Hearse	Body	Driver Door Switch																																																								
ALL	2007	Hearse	Body	Driver Position Module																																																								
ALL	2007	Hearse	Body	HVAC Control Module																																																								
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																								
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																								
ALL	2007	Hearse	Body	Passenger Door Switch																																																								
ALL	2007	Hearse	Body	Passenger Presence System																																																								
ALL	2007	Hearse	Body	Radio																																																								
ALL	2007	Hearse	Body	Rear Heated Seat Module																																																								
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																																								
ALL	2007	Hearse	Body	Theft Deterrent Module																																																								
ALL	2007	Limousine	Powertrain	Engine Control Module																																																								
ALL	2007	Limousine	Powertrain	Transmission Control Module																																																								
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																								
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																																								
ALL	2007	Limousine	Body	Amplifier (Bose)																																																								
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																																								
ALL	2007	Limousine	Body	Body Control Module																																																								
ALL	2007	Limousine	Body	Digital Radio Receiver																																																								
ALL	2007	Limousine	Body	Driver Door Switch																																																								
ALL	2007	Limousine	Body	Driver Position Module																																																								
ALL	2007	Limousine	Body	HVAC Control Module																																																								
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																									
ALL	2007	Limousine	Body	Passenger Door Switch																																																									
ALL	2007	Limousine	Body	Passenger Presence System																																																									
ALL	2007	Limousine	Body	Radio																																																									
ALL	2007	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	Limousine	Body	Theft Deterrent Module																																																										
ALL	2008	Hearse	Powertrain	Engine Control Module																																																										
ALL	2008	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2008	Hearse	Body	Amplifier (Bose)																																																										
ALL	2008	Hearse	Body	Body Control Module																																																										
ALL	2008	Hearse	Body	Climate Control Seat Module																																																										
ALL	2008	Hearse	Body	Digital Radio Receiver																																																										
ALL	2008	Hearse	Body	Driver Door Switch																																																										
ALL	2008	Hearse	Body	Driver Position Module																																																										
ALL	2008	Hearse	Body	HVAC Control Module																																																										
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2008	Hearse	Body	Passenger Door Switch																																																										
ALL	2008	Hearse	Body	Passenger Presence System																																																										
ALL	2008	Hearse	Body	Radio																																																										
ALL	2008	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	Hearse	Body	Theft Deterrent Module																																																										
ALL	2008	Limousine	Powertrain	Engine Control Module																																																										
ALL	2008	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2008	Limousine	Body	Amplifier (Bose)																																																										
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2008	Limousine	Body	Body Control Module																																																										
ALL	2008	Limousine	Body	Climate Control Seat Module																																																										
ALL	2008	Limousine	Body	Digital Radio Receiver																																																										
ALL	2008	Limousine	Body	Driver Door Switch																																																										
ALL	2008	Limousine	Body	Driver Position Module																																																										
ALL	2008	Limousine	Body	HVAC Control Module																																																										
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2008	Limousine	Body	Passenger Door Switch																																																										
ALL	2008	Limousine	Body	Passenger Presence System																																																										
ALL	2008	Limousine	Body	Radio																																																										
ALL	2008	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	Limousine	Body	Theft Deterrent Module																																																										
ALL	2009	Hearse	Powertrain	Engine Control Module																																																										
ALL	2009	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2009	Hearse	Body	Amplifier (Bose)																																																										
ALL	2009	Hearse	Body	Body Control Module																																																										
ALL	2009	Hearse	Body	Climate Control Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
ALL	2009	Hearse	Body	Digital Radio Receiver																																																								
ALL	2009	Hearse	Body	Driver Door Switch																																																								
ALL	2009	Hearse	Body	Driver Position Module																																																								
ALL	2009	Hearse	Body	HVAC Control Module																																																								
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																								
ALL	2009	Hearse	Body	Passenger Door Switch																																																								
ALL	2009	Hearse	Body	Passenger Presence System																																																								
ALL	2009	Hearse	Body	Radio																																																								
ALL	2009	Hearse	Body	Rear Heated Seat Module																																																								
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																																								
ALL	2009	Hearse	Body	Theft Deterrent Module																																																								
ALL	2009	Limousine	Powertrain	Engine Control Module																																																								
ALL	2009	Limousine	Powertrain	Transmission Control Module																																																								
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																								
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																																								
ALL	2009	Limousine	Body	Amplifier (Bose)																																																								
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																								
ALL	2009	Limousine	Body	Body Control Module																																																								
ALL	2009	Limousine	Body	Climate Control Seat Module																																																								
ALL	2009	Limousine	Body	Digital Radio Receiver																																																								
ALL	2009	Limousine	Body	Driver Door Switch																																																								
ALL	2009	Limousine	Body	Driver Position Module																																																								
ALL	2009	Limousine	Body	HVAC Control Module																																																								
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																								
ALL	2009	Limousine	Body	Passenger Door Switch																																																								
ALL	2009	Limousine	Body	Passenger Presence System																																																								
ALL	2009	Limousine	Body	Radio																																																								
ALL	2009	Limousine	Body	Rear Heated Seat Module																																																								
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																																								
ALL	2009	Limousine	Body	Theft Deterrent Module																																																								
ALL	2010	Hearse	Powertrain	Engine Control Module																																																								
ALL	2010	Hearse	Powertrain	Transmission Control Module																																																								
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																								
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																																								
ALL	2010	Hearse	Body	Amplifier (Bose)																																																								
ALL	2010	Hearse	Body	Body Control Module																																																								
ALL	2010	Hearse	Body	Climate Control Seat Module																																																								
ALL	2010	Hearse	Body	Digital Radio Receiver																																																								
ALL	2010	Hearse	Body	Driver Door Switch																																																								
ALL	2010	Hearse	Body	Driver Position Module																																																								
ALL	2010	Hearse	Body	HVAC Control Module																																																								
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																								
ALL	2010	Hearse	Body	Passenger Door Switch																																																								
ALL	2010	Hearse	Body	Passenger Presence System																																																								
ALL	2010	Hearse	Body	Radio																																																								
ALL	2010	Hearse	Body	Rear Heated Seat Module																																																								
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																																								
ALL	2010	Hearse	Body	Theft Deterrent Module																																																								
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																																								
ALL	2010	Limousine	Powertrain	Engine Control Module																																																								
ALL	2010	Limousine	Powertrain	Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																									
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2010	Limousine	Body	Amplifier (Bose)																																																										
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2010	Limousine	Body	Body Control Module																																																										
ALL	2010	Limousine	Body	Climate Control Seat Module																																																										
ALL	2010	Limousine	Body	Digital Radio Receiver																																																										
ALL	2010	Limousine	Body	Driver Door Switch																																																										
ALL	2010	Limousine	Body	Driver Position Module																																																										
ALL	2010	Limousine	Body	HVAC Control Module																																																										
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2010	Limousine	Body	Passenger Door Switch																																																										
ALL	2010	Limousine	Body	Passenger Presence System																																																										
ALL	2010	Limousine	Body	Radio																																																										
ALL	2010	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	Limousine	Body	Theft Deterrent Module																																																										
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																																										
ALL	2011	Hearse	Powertrain	Engine Control Module																																																										
ALL	2011	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2011	Hearse	Body	Amplifier (Bose)																																																										
ALL	2011	Hearse	Body	Body Control Module																																																										
ALL	2011	Hearse	Body	Climate Control Seat Module																																																										
ALL	2011	Hearse	Body	Digital Radio Receiver																																																										
ALL	2011	Hearse	Body	Driver Door Switch																																																										
ALL	2011	Hearse	Body	Driver Position Module																																																										
ALL	2011	Hearse	Body	HVAC Control Module																																																										
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2011	Hearse	Body	Passenger Door Switch																																																										
ALL	2011	Hearse	Body	Passenger Presence System																																																										
ALL	2011	Hearse	Body	Radio																																																										
ALL	2011	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2011	Hearse	Body	Theft Deterrent Module																																																										
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																																										
ALL	2011	Limousine	Powertrain	Engine Control Module																																																										
ALL	2011	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2011	Limousine	Body	Amplifier (Bose)																																																										
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2011	Limousine	Body	Body Control Module																																																										
ALL	2011	Limousine	Body	Climate Control Seat Module																																																										
ALL	2011	Limousine	Body	Digital Radio Receiver																																																										
ALL	2011	Limousine	Body	Driver Door Switch																																																										
ALL	2011	Limousine	Body	Driver Position Module																																																										
ALL	2011	Limousine	Body	HVAC Control Module																																																										
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2011	Limousine	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
ALL	2011	Limousine	Body	Passenger Presence System																																																								
ALL	2011	Limousine	Body	Radio																																																								
ALL	2011	Limousine	Body	Rear Heated Seat Module																																																								
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																																								
ALL	2011	Limousine	Body	Theft Deterrent Module																																																								
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																												
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2004	ALL	Chassis	ESC																																																											
C	2004	ALL	Chassis	Rear Wheel Steering																																																												
C	2004	ALL	Chassis	Tire Pressure Monitor																																																												
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2004	ALL	Chassis	VSES																																																											
C	2004	ALL	Body	Amplifier (Bose)																																																											
C	2004	ALL	Body	Body Control Module																																																											
C	2004	ALL	Body	CD Changer																																																											
C	2004	ALL	Body	Chime																																																											
C	2004	ALL	Body	Driver Door Module																																																											
C	2004	ALL	Body	Driver Seat Module																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
C	2004	ALL	Body	Instrument Panel Cluster																																																											
C	2004	ALL	Body	OnStar																																																										
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Base Radio																																																										
C	2004	ALL	Body	Uplevel Radio																																																										
C	2004	ALL	Body	Navigation Radio																																																										
C	2004	ALL	Body	Rear Aux. Climate Module	V																																																										
C	2004	ALL	Body	Rear HVAC																																																											
C	2004	ALL	Body	Rear Seat Audio																																																											
C	2004	ALL	Body	Rear Seat Entertainment																																																											
C	2004	ALL	Body	Supplemental Inflatable Restraint		V																																																									
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																												
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																												
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2005	ALL	Chassis	ESC																																																											
C	2005	ALL	Chassis	Rear Wheel Steering																																																												
C	2005	ALL	Chassis	Tire Pressure Monitor																																																												
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2005	ALL	Chassis	VSES																																																											
C	2005	ALL	Body	Amplifier (Bose)																																																											
C	2005	ALL	Body	Body Control Module																																																											
C	2005	ALL	Body	CD Changer																																																											
C	2005	ALL	Body	Chime																																																											
C	2005	ALL	Body	Disc Player and Video Display																																																											
C	2005	ALL	Body	Driver Door Module																																																											
C	2005	ALL	Body	Driver Seat Module																																																											
C	2005	ALL	Body	Generator Battery Control Module																																																											
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																												
C	2005	ALL	Body	Instrument Panel Cluster																																																												
C	2005	ALL	Body	Passenger Door Module																																																												
C	2005	ALL	Body	Passenger Presence System																																																												
C	2005	ALL	Body	Base Radio																																																												
C	2005	ALL	Body	Uplevel Radio																																																												
C	2005	ALL	Body	Navigation Radio																																																												
C	2005	ALL	Body	Rear Aux. Climate Module	V																																																											
C	2005	ALL	Body	Rear HVAC																																																												
C	2005	ALL	Body	Rear Seat Audio																																																												
C	2005	ALL	Body	Remote Function Actuation																																																												
C	2005	ALL	Body	Supplemental Inflatable Restraint		V																																																										
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																												
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																												
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																												
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2006	ALL	Chassis	ESC																																																											
C	2006	ALL	Chassis	Tire Pressure Monitor																																																											
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2006	ALL	Chassis	VSES																																																											
C	2006	ALL	Body	Amplifier (Bose)																																																												
C	2006	ALL	Body	Body Control Module																																																												
C	2006	ALL	Body	CD Changer																																																												
C	2006	ALL	Body	Chime																																																												
C	2006	ALL	Body	Disc Player and Video Display																																																												
C	2006	ALL	Body	Driver Door Module																																																												
C	2006	ALL	Body	Driver Seat Module																																																												
C	2006	ALL	Body	Generator Battery Control Module																																																												
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																												
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
C	2006	ALL	Body	Instrument Panel Cluster																																																												
C	2006	ALL	Body	Passenger Door Module																																																												
C	2006	ALL	Body	Passenger Presence System																																																												
C	2006	ALL	Body	Base Radio																																																												
C	2006	ALL	Body	Uplevel Radio																																																												
C	2006	ALL	Body	Navigation Radio																																																												
C	2006	ALL	Body	Rear Aux. Climate Module	V																																																											
C	2006	ALL	Body	Rear HVAC																																																												
C	2006	ALL	Body	Rear Seat Audio																																																												
C	2006	ALL	Body	Supplemental Inflatable Restraint			V																																																								
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	ALL	Chassis	Electronic Brake Control Module				V	V																																																						
C	2007	ALL	Chassis	Electronic Suspension Control																																																												
C	2007	ALL	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2007	ALL	Body	Assist Step Controller																																																										
C	2007	ALL	Body	Body Control Module																																																										
C	2007	ALL	Body	Body Control Module (aux.)																																																										
C	2007	ALL	Body	Digital Radio Receiver																																																										
C	2007	ALL	Body	Driver Door Switch																																																										
C	2007	ALL	Body	HVAC Control Module						V																																																				
C	2007	ALL	Body	Inside Rear View Mirror Module																																																										
C	2007	ALL	Body	Instrument Panel Cluster																																																										
C	2007	ALL	Body	Lift Gate Module																																																										
C	2007	ALL	Body	Memory Seat Module							V																																																			
C	2007	ALL	Body	Park Assist Module								V																																																		
C	2007	ALL	Body	Passenger Door Switch																																																										
C	2007	ALL	Body	Passenger Presence System																																																										
C	2007	ALL	Body	Radio																																																										
C	2007	ALL	Body	Rear Heated Seat Module																																																										
C	2007	ALL	Body	Rear HVAC/RSA																																																										
C	2007	ALL	Body	Rollover Sensor																																																										
C	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2007	ALL	Body	Theft Deterrent Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	ALL	Chassis	Electronic Brake Control Module					V																																																					
C	2008	ALL	Chassis	Electronic Suspension Control																																																										
C	2008	ALL	Chassis	Trailer Brake Control Module																																																										
C	2008	ALL	Body	Amplifier (Bose)																																																										
C	2008	ALL	Body	Assist Step Controller																																																										
C	2008	ALL	Body	Body Control Module																																																										
C	2008	ALL	Body	Body Control Module (aux.)																																																										
C	2008	ALL	Body	Digital Radio Receiver																																																										
C	2008	ALL	Body	Driver Door Switch																																																										
C	2008	ALL	Body	HVAC Control Module						V																																																				
C	2008	ALL	Body	Inside Rear View Mirror Module																																																										
C	2008	ALL	Body	Instrument Panel Cluster																																																										
C	2008	ALL	Body	Lift Gate Module																																																										
C	2008	ALL	Body	Memory Seat Module							V																																																			
C	2008	ALL	Body	Park Assist Module								V																																																		
C	2008	ALL	Body	Passenger Door Switch																																																										
C	2008	ALL	Body	Passenger Presence System																																																										
C	2008	ALL	Body	Radio																																																										
C	2008	ALL	Body	Rear Heated Seat Module																																																										
C	2008	ALL	Body	Rear HVAC/RSA																																																										
C	2008	ALL	Body	Rollover Sensor																																																										
C	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2008	ALL	Body	Theft Deterrent Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	ALL	Chassis	Electronic Brake Control Module					V																																																					
C	2009	ALL	Chassis	Electronic Suspension Control																																																										
C	2009	ALL	Chassis	Trailer Brake Control Module				V																																																						

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2009	ALL	Body	Amplifier (Bose)																																																											
C	2009	ALL	Body	Assist Step Controller																																																											
C	2009	ALL	Body	Body Control Module																																																										
C	2009	ALL	Body	Body Control Module (aux.)																																																										
C	2009	ALL	Body	Digital Radio Receiver																																																										
C	2009	ALL	Body	Driver Door Switch																																																										
C	2009	ALL	Body	HVAC Control Module						V																																																				
C	2009	ALL	Body	Inside Rear View Mirror Module																																																											
C	2009	ALL	Body	Instrument Panel Cluster																																																											
C	2009	ALL	Body	Left Side Object Detection Module																																																											
C	2009	ALL	Body	Lift Gate Module																																																											
C	2009	ALL	Body	Memory Seat Module							V																																																			
C	2009	ALL	Body	Park Assist Module								V																																																		
C	2009	ALL	Body	Passenger Door Switch																																																											
C	2009	ALL	Body	Passenger Presence System																																																											
C	2009	ALL	Body	Radio																																																											
C	2009	ALL	Body	Rear Heated Seat Module																																																											
C	2009	ALL	Body	Rear HVAC/RSA																																																											
C	2009	ALL	Body	Right Side Object Detection Module																																																											
C	2009	ALL	Body	Rollover Sensor																																																											
C	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
C	2009	ALL	Body	Theft Deterrent Module																																																											
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																																
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																														
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2010	ALL	Chassis	Electronic Brake Control Module					V																																																						
C	2010	ALL	Chassis	Electronic Suspension Control																																																											
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	ALL	Body	Amplifier (Bose)																																																											
C	2010	ALL	Body	Assist Step Controller																																																											
C	2010	ALL	Body	Body Control Module																																																											
C	2010	ALL	Body	Body Control Module (aux.)																																																											
C	2010	ALL	Body	Digital Radio Receiver																																																											
C	2010	ALL	Body	Driver Door Switch																																																											
C	2010	ALL	Body	HVAC Control Module						V																																																					
C	2010	ALL	Body	Inside Rear View Mirror Module																																																											
C	2010	ALL	Body	Instrument Panel Cluster																																																											
C	2010	ALL	Body	Left Side Object Detection Module																																																											
C	2010	ALL	Body	Lift Gate Module																																																											
C	2010	ALL	Body	Memory Seat Module							V																																																				
C	2010	ALL	Body	Park Assist Module																																																											
C	2010	ALL	Body	Passenger Door Switch																																																											
C	2010	ALL	Body	Passenger Presence System																																																											
C	2010	ALL	Body	Radio																																																											
C	2010	ALL	Body	Rear Heated Seat Module																																																											
C	2010	ALL	Body	Rear HVAC/RSA																																																											
C	2010	ALL	Body	Right Side Object Detection Module																																																											
C	2010	ALL	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2010	ALL	Body	Theft Deterrent Module																																																												
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																																												
E	2004	ALL	Chassis	Electronic Suspension Control													V	V																																														
E	2004	ALL	Chassis	Tire Pressure Monitor																																																												
E	2004	ALL	Chassis	VES																																																												
E	2004	ALL	Body	Amplifier (Bose)																																																												
E	2004	ALL	Body	Amplifier (Delco)																																																												
E	2004	ALL	Body	Climate Control Panel																																																												
E	2004	ALL	Body	Dash Integration Module																																																												
E	2004	ALL	Body	Disc Player and Video Display																																																												
E	2004	ALL	Body	Driver Door Switch																																																												
E	2004	ALL	Body	Driver Door Module																																																												
E	2004	ALL	Body	Passenger Door Module																																																												
E	2004	ALL	Body	Left Rear Door Module																																																												
E	2004	ALL	Body	Right Rear Door Module																																																												
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																												
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																												
E	2004	ALL	Body	Instrument Panel Cluster																																																												
E	2004	ALL	Body	Memory Seat Module															V	V																																												
E	2004	ALL	Body	OnStar																																																												
E	2004	ALL	Body	Personalization																																																												
E	2004	ALL	Body	Base Radio																																																												
E	2004	ALL	Body	Navigation Radio																																																												
E	2004	ALL	Body	Rear Integration Module																																																												
E	2004	ALL	Body	Rear Seat Module																	V	V	V	V	V																																							
E	2004	ALL	Body	Remote Function Actuation																																																												
E	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2004	ALL	Body	TV Antenna Module																																																												
E	2004	ALL	Body	Vehicle Theft Deterrent																																																												
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																																												
E	2005	ALL	Chassis	Electronic Suspension Control													V	V																																														
E	2005	ALL	Chassis	Tire Pressure Monitor																																																												
E	2005	ALL	Chassis	VES																																																												
E	2005	ALL	Body	Amplifier (Bose)																																																												
E	2005	ALL	Body	Amplifier (Delco)																																																												
E	2005	ALL	Body	Climate Control Panel																																																												
E	2005	ALL	Body	Dash Integration Module																																																												
E	2005	ALL	Body	Disc Player and Video Display																																																												
E	2005	ALL	Body	Driver Door Switch																																																												
E	2005	ALL	Body	Driver Door Module																																																												
E	2005	ALL	Body	Passenger Door Module																																																												
E	2005	ALL	Body	Left Rear Door Module																																																												
E	2005	ALL	Body	Right Rear Door Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																													
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																													
E	2005	ALL	Body	Instrument Panel Cluster																																																													
E	2005	ALL	Body	Memory Seat Module															V	V																																												
E	2005	ALL	Body	Personalization																																																												
E	2005	ALL	Body	Base Radio																																																												
E	2005	ALL	Body	Navigation Radio																																																												
E	2005	ALL	Body	Rear Integration Module																																																												
E	2005	ALL	Body	Rear Seat Module																	V	V	V	V	V																																							
E	2005	ALL	Body	Remote Function Actuation																																																												
E	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2005	ALL	Body	TV Antenna Module																																																												
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																												
E	2005	ALL	Body	Vehicle Theft Deterrent																																																												
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																												
E	2006	ALL	Chassis	Electronic Suspension Control													V	V																																													
E	2006	ALL	Chassis	Tire Pressure Monitor																																																												
E	2006	ALL	Chassis	VES																																																											
E	2006	ALL	Body	Amplifier (Bose)																																																											
E	2006	ALL	Body	Amplifier (Delco)																																																											
E	2006	ALL	Body	Climate Control Panel																																																											
E	2006	ALL	Body	Dash Integration Module																																																											
E	2006	ALL	Body	Disc Player and Video Display																																																											
E	2006	ALL	Body	Driver Door Switch																																																											
E	2006	ALL	Body	Driver Door Module																																																											
E	2006	ALL	Body	Passenger Door Module																																																											
E	2006	ALL	Body	Left Rear Door Module																																																											
E	2006	ALL	Body	Right Rear Door Module																																																											
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																											
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																											
E	2006	ALL	Body	Instrument Panel Cluster																																																											
E	2006	ALL	Body	Lift Gate Module																																																											
E	2006	ALL	Body	Memory Seat Module															V	V																																												
E	2006	ALL	Body	Personalization																																																												
E	2006	ALL	Body	Base Radio																																																											
E	2006	ALL	Body	Navigation Radio																																																											
E	2006	ALL	Body	Rear Integration Module																																																											
E	2006	ALL	Body	Rear Seat Module																	V	V	V	V	V																																							
E	2006	ALL	Body	Remote Function Actuation																																																												
E	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
E	2006	ALL	Body	Vehicle Theft Deterrent																																																												
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2007	ALL	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
E	2007	ALL	Chassis	Electronic Suspension Control																																																										
E	2007	ALL	Body	Amplifier (Bose)																																																										
E	2007	ALL	Body	Body Control Module																																																										
E	2007	ALL	Body	Body Control Module (aux.)																																																										
E	2007	ALL	Body	Digital Radio Receiver																																																										
E	2007	ALL	Body	Driver Door Switch																																																										
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2007	ALL	Body	HVAC Control Module																																																										
E	2007	ALL	Body	Instrument Panel Cluster																																																										
E	2007	ALL	Body	Lift Gate Module																																																										
E	2007	ALL	Body	Memory Seat Module							V																																																			
E	2007	ALL	Body	Park Assist Module								V																																																		
E	2007	ALL	Body	Passenger Door Switch																																																										
E	2007	ALL	Body	Passenger Presence System																																																										
E	2007	ALL	Body	Radio																																																										
E	2007	ALL	Body	Rear HVAC/RSA																																																										
E	2007	ALL	Body	Rear Seat Module																																																										
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																										
E	2007	ALL	Body	Rollover Sensor																																																										
E	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2007	ALL	Body	Theft Deterrent Module																																																										
E	2007	ALL	Body	TV Antenna Module																																																										
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																										
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																										
E	2008	ALL	Chassis	Electronic Brake Control Module																																																										
E	2008	ALL	Chassis	Electronic Suspension Control																																																										
E	2008	ALL	Body	Amplifier (Bose)																																																										
E	2008	ALL	Body	Body Control Module																																																										
E	2008	ALL	Body	Body Control Module (aux.)																																																										
E	2008	ALL	Body	Digital Radio Receiver																																																										
E	2008	ALL	Body	Driver Door Switch																																																										
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																										
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																										
E	2008	ALL	Body	HVAC Control Module																																																										
E	2008	ALL	Body	Instrument Panel Cluster																																																										
E	2008	ALL	Body	Lift Gate Module																																																										
E	2008	ALL	Body	Memory Seat Module							V																																																			
E	2008	ALL	Body	Park Assist Module								V																																																		
E	2008	ALL	Body	Passenger Door Switch																																																										
E	2008	ALL	Body	Passenger Presence System																																																										
E	2008	ALL	Body	Radio																																																										
E	2008	ALL	Body	Rear HVAC/RSA																																																										
E	2008	ALL	Body	Rear Seat Module																																																										
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
E	2008	ALL	Body	Rollover Sensor																																																										
E	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
E	2008	ALL	Body	Theft Deterrent Module																																																										
E	2008	ALL	Body	TV Antenna Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2009	ALL	Chassis	Electronic Brake Control Module																																																												
E	2009	ALL	Chassis	Electronic Suspension Control																																																												
E	2009	ALL	Body	Amplifier (Bose)																																																												
E	2009	ALL	Body	Body Control Module																																																												
E	2009	ALL	Body	Body Control Module (aux.)																																																												
E	2009	ALL	Body	Digital Radio Receiver																																																												
E	2009	ALL	Body	Driver Door Switch																																																												
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																												
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																												
E	2009	ALL	Body	HVAC Control Module																																																												
E	2009	ALL	Body	Instrument Panel Cluster																																																												
E	2009	ALL	Body	Lift Gate Module																																																												
E	2009	ALL	Body	Memory Seat Module							V																																																					
E	2009	ALL	Body	Park Assist Module								V																																																				
E	2009	ALL	Body	Passenger Door Switch																																																												
E	2009	ALL	Body	Passenger Presence System																																																												
E	2009	ALL	Body	Radio																																																												
E	2009	ALL	Body	Rear HVAC/RSA																																																												
E	2009	ALL	Body	Rear Seat Module																																																												
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																												
E	2009	ALL	Body	Rollover Sensor																																																												
E	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2009	ALL	Body	Theft Deterrent Module																																																												
E	2009	ALL	Body	TV Antenna Module																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2004	ALL	Chassis	ESC																																																											
K	2004	ALL	Chassis	Rear Wheel Steering																																																												
K	2004	ALL	Chassis	Tire Pressure Monitor																																																												
K	2004	ALL	Chassis	VSES																																																											
K	2004	ALL	Body	Amplifier (Bose)																																																												
K	2004	ALL	Body	Body Control Module																																																												
K	2004	ALL	Body	CD Changer																																																												
K	2004	ALL	Body	Chime																																																												
K	2004	ALL	Body	Driver Door Module																																																												
K	2004	ALL	Body	Driver Seat Module																																																												
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2004	ALL	Body	Instrument Panel Cluster																																																												
K	2004	ALL	Body	OnStar																																																											
K	2004	ALL	Body	Passenger Door Module																																																											
K	2004	ALL	Body	Passenger Presence System																																																											
K	2004	ALL	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2004	ALL	Body	Uplevel Radio																																																												
K	2004	ALL	Body	Navigation Radio																																																												
K	2004	ALL	Body	Rear Aux. Climate Module	V																																																											
K	2004	ALL	Body	Rear HVAC																																																												
K	2004	ALL	Body	Rear Seat Audio																																																												
K	2004	ALL	Body	Rear Seat Entertainment																																																												
K	2004	ALL	Body	Supplemental Inflatable Restraint		V																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																												
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																												
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2005	ALL	Chassis	ESC																																																											
K	2005	ALL	Chassis	Rear Wheel Steering																																																												
K	2005	ALL	Chassis	Tire Pressure Monitor																																																												
K	2005	ALL	Chassis	VSES																																																												
K	2005	ALL	Body	Amplifier (Bose)																																																												
K	2005	ALL	Body	Body Control Module																																																												
K	2005	ALL	Body	CD Changer																																																												
K	2005	ALL	Body	Chime																																																												
K	2005	ALL	Body	Disc Player and Video Display																																																												
K	2005	ALL	Body	Driver Door Module																																																												
K	2005	ALL	Body	Driver Seat Module																																																												
K	2005	ALL	Body	Generator Battery Control Module																																																												
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2005	ALL	Body	Instrument Panel Cluster																																																												
K	2005	ALL	Body	Passenger Door Module																																																												
K	2005	ALL	Body	Passenger Presence System																																																												
K	2005	ALL	Body	Base Radio																																																												
K	2005	ALL	Body	Uplevel Radio																																																												
K	2005	ALL	Body	Navigation Radio																																																												
K	2005	ALL	Body	Rear Aux. Climate Module	V																																																											
K	2005	ALL	Body	Rear HVAC																																																												
K	2005	ALL	Body	Rear Seat Audio																																																												
K	2005	ALL	Body	Remote Function Actuation																																																												
K	2005	ALL	Body	Supplemental Inflatable Restraint		V																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																												
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																												
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2006	ALL	Chassis	ESC																																																											
K	2006	ALL	Chassis	Tire Pressure Monitor																																																												
K	2006	ALL	Chassis	VSES																																																												
K	2006	ALL	Body	Amplifier (Bose)																																																												
K	2006	ALL	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2006	ALL	Body	CD Changer																																																											
K	2006	ALL	Body	Chime																																																											
K	2006	ALL	Body	Disc Player and Video Display																																																												
K	2006	ALL	Body	Driver Door Module																																																												
K	2006	ALL	Body	Driver Seat Module																																																												
K	2006	ALL	Body	Generator Battery Control Module																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2006	ALL	Body	Instrument Panel Cluster																																																												
K	2006	ALL	Body	Passenger Door Module																																																												
K	2006	ALL	Body	Passenger Presence System																																																												
K	2006	ALL	Body	Base Radio																																																												
K	2006	ALL	Body	Uplevel Radio																																																												
K	2006	ALL	Body	Navigation Radio																																																												
K	2006	ALL	Body	Rear Aux. Climate Module	V																																																											
K	2006	ALL	Body	Rear HVAC																																																												
K	2006	ALL	Body	Rear Seat Audio																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint			V																																																									
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2007	ALL	Chassis	Electronic Brake Control Module				V	V																																																							
K	2007	ALL	Chassis	Electronic Suspension Control																																																												
K	2007	ALL	Body	Amplifier (Bose)																																																												
K	2007	ALL	Body	Assist Step Controller																																																												
K	2007	ALL	Body	Body Control Module																																																												
K	2007	ALL	Body	Body Control Module (aux.)																																																												
K	2007	ALL	Body	Digital Radio Receiver																																																												
K	2007	ALL	Body	Driver Door Switch																																																												
K	2007	ALL	Body	HVAC Control Module						V																																																						
K	2007	ALL	Body	Inside Rear View Mirror Module																																																												
K	2007	ALL	Body	Instrument Panel Cluster																																																												
K	2007	ALL	Body	Lift Gate Module																																																												
K	2007	ALL	Body	Memory Seat Module							V																																																					
K	2007	ALL	Body	Park Assist Module								V																																																				
K	2007	ALL	Body	Passenger Door Switch																																																												
K	2007	ALL	Body	Passenger Presence System																																																												
K	2007	ALL	Body	Radio																																																												
K	2007	ALL	Body	Rear Heated Seat Module																																																												
K	2007	ALL	Body	Rear HVAC/RSA																																																												
K	2007	ALL	Body	Rollover Sensor																																																												
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2007	ALL	Body	Theft Deterrent Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2008	ALL	Chassis	Electronic Brake Control Module					V																																																							
K	2008	ALL	Chassis	Electronic Suspension Control																																																												
K	2008	ALL	Chassis	Trailer Brake Control Module																																																												
K	2008	ALL	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2008	ALL	Body	Assist Step Controller																																																										
K	2008	ALL	Body	Body Control Module																																																										
K	2008	ALL	Body	Body Control Module (aux.)																																																										
K	2008	ALL	Body	Digital Radio Receiver																																																										
K	2008	ALL	Body	Driver Door Switch																																																										
K	2008	ALL	Body	HVAC Control Module						V																																																				
K	2008	ALL	Body	Inside Rear View Mirror Module																																																										
K	2008	ALL	Body	Instrument Panel Cluster																																																										
K	2008	ALL	Body	Lift Gate Module																																																										
K	2008	ALL	Body	Memory Seat Module							V																																																			
K	2008	ALL	Body	Park Assist Module								V																																																		
K	2008	ALL	Body	Passenger Door Switch																																																										
K	2008	ALL	Body	Passenger Presence System																																																										
K	2008	ALL	Body	Radio																																																										
K	2008	ALL	Body	Rear Heated Seat Module																																																										
K	2008	ALL	Body	Rear HVAC/RSA																																																										
K	2008	ALL	Body	Rollover Sensor																																																										
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2008	ALL	Body	Theft Deterrent Module																																																										
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	ALL	Chassis	Electronic Brake Control Module					V																																																					
K	2009	ALL	Chassis	Electronic Suspension Control																																																										
K	2009	ALL	Chassis	Trailer Brake Control Module				V																																																						
K	2009	ALL	Body	Amplifier (Bose)																																																										
K	2009	ALL	Body	Assist Step Controller																																																										
K	2009	ALL	Body	Body Control Module																																																										
K	2009	ALL	Body	Body Control Module (aux.)																																																										
K	2009	ALL	Body	Digital Radio Receiver																																																										
K	2009	ALL	Body	Driver Door Switch																																																										
K	2009	ALL	Body	HVAC Control Module						V																																																				
K	2009	ALL	Body	Inside Rear View Mirror Module																																																										
K	2009	ALL	Body	Instrument Panel Cluster																																																										
K	2009	ALL	Body	Left Side Object Detection Module																																																										
K	2009	ALL	Body	Lift Gate Module																																																										
K	2009	ALL	Body	Memory Seat Module							V																																																			
K	2009	ALL	Body	Park Assist Module								V																																																		
K	2009	ALL	Body	Passenger Door Switch																																																										
K	2009	ALL	Body	Passenger Presence System																																																										
K	2009	ALL	Body	Radio																																																										
K	2009	ALL	Body	Rear Heated Seat Module																																																										
K	2009	ALL	Body	Rear HVAC/RSA																																																										
K	2009	ALL	Body	Right Side Object Detection Module																																																										
K	2009	ALL	Body	Rollover Sensor																																																										
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2009	ALL	Body	Theft Deterrent Module																																																										
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																															
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																														

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	ALL	Chassis	Electronic Brake Control Module					V																																																							
K	2010	ALL	Chassis	Electronic Suspension Control																																																												
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	ALL	Body	Amplifier (Bose)																																																												
K	2010	ALL	Body	Assist Step Controller																																																												
K	2010	ALL	Body	Body Control Module																																																												
K	2010	ALL	Body	Body Control Module (aux.)																																																												
K	2010	ALL	Body	Digital Radio Receiver																																																												
K	2010	ALL	Body	Driver Door Switch																																																												
K	2010	ALL	Body	HVAC Control Module						V																																																						
K	2010	ALL	Body	Inside Rear View Mirror Module																																																												
K	2010	ALL	Body	Instrument Panel Cluster																																																												
K	2010	ALL	Body	Left Side Object Detection Module																																																												
K	2010	ALL	Body	Lift Gate Module																																																												
K	2010	ALL	Body	Memory Seat Module							V																																																					
K	2010	ALL	Body	Park Assist Module																																																												
K	2010	ALL	Body	Passenger Door Switch																																																												
K	2010	ALL	Body	Passenger Presence System																																																												
K	2010	ALL	Body	Radio																																																												
K	2010	ALL	Body	Rear Heated Seat Module																																																												
K	2010	ALL	Body	Rear HVAC/RSA																																																												
K	2010	ALL	Body	Right Side Object Detection Module																																																												
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2010	ALL	Body	Theft Deterrent Module																																																												
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																												
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																												
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																												
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																												
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2010	SRX	Chassis	Electronic Brake Control Module																																																												
N	2010	SRX	Chassis	Parking Brake Control Module																																																												
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2010	SRX	Chassis	Suspension Control Module																																																												
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2010	SRX	Body	Passenger Presence Module																																																												
N	2010	SRX	Body	Instrument Cluster																																																												
N	2010	SRX	Body	Headlamp Control Module																																																												
N	2010	SRX	Body	Trailer Interface Control Module																																																												
N	2010	SRX	Body	Radio																																																												
N	2010	SRX	Body	Rear Audio Control Module																																																												
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																												
N	2010	SRX	Body	Multimedia Player Interface Module																																																												
N	2010	SRX	Body	Mobile Telephone Control Module																																																												
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																											
N	2010	SRX	Body	Liftgate Control Module																																																											
N	2010	SRX	Body	Seat Memory Control Module																						V																																						
N	2010	SRX	Body	Front Seat Heating Control Module																																																											
N	2010	SRX	Body	Rear Seat Heating Control Module																																																											
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2010	SRX	Body	Parking Assist Control Module																																																											
N	2010	SRX	Body	Steering Column Lock Control Module																																																											
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																											
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																											
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																											
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																											
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																											
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																											
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2011	SRX	Chassis	Electronic Brake Control Module																																																											
N	2011	SRX	Chassis	Parking Brake Control Module																																																											
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2011	SRX	Chassis	Suspension Control Module																																																											
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2011	SRX	Body	Passenger Presence Module																																																											
N	2011	SRX	Body	Instrument Cluster																																																											
N	2011	SRX	Body	Headlamp Control Module																																																											
N	2011	SRX	Body	Trailer Interface Control Module																																																											
N	2011	SRX	Body	Radio																																																											
N	2011	SRX	Body	Rear Audio Control Module																																																											
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																											
N	2011	SRX	Body	Multimedia Player Interface Module																																																											
N	2011	SRX	Body	Mobile Telephone Control Module																																																											
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																											
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																											
N	2011	SRX	Body	Liftgate Control Module																																																											
N	2011	SRX	Body	Seat Memory Control Module																																																											
N	2011	SRX	Body	Front Seat Heating Control Module																																																											
N	2011	SRX	Body	Rear Seat Heating Control Module																																																											
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2011	SRX	Body	Parking Assist Control Module																																																											
N	2011	SRX	Body	Steering Column Lock Control Module																																																											
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																											
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																											
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2012	SRX	Chassis	Electronic Brake Control Module																																																											
N	2012	SRX	Chassis	Parking Brake Control Module																																																											
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2012	SRX	Chassis	Suspension Control Module																																																											
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2012	SRX	Body	Passenger Presence Module																																																											
N	2012	SRX	Body	Instrument Cluster																																																											
N	2012	SRX	Body	Headlamp Control Module																																																											
N	2012	SRX	Body	Trailer Interface Control Module																																																											
N	2012	SRX	Body	Radio																																																											
N	2012	SRX	Body	Rear Audio Control Module																																																											
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																											
N	2012	SRX	Body	Multimedia Player Interface Module																																																											
N	2012	SRX	Body	Mobile Telephone Control Module																																																											
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																																											
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																											
N	2012	SRX	Body	Liftgate Control Module																																																											
N	2012	SRX	Body	Seat Memory Control Module																																																											
N	2012	SRX	Body	Front Seat Heating Control Module																																																											
N	2012	SRX	Body	Rear Seat Heating Control Module																																																											
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2012	SRX	Body	Parking Assist Control Module																																																											
N	2012	SRX	Body	Steering Column Lock Control Module																																																											
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2013	SRX	Chassis	Electronic Brake Control Module																																																											
N	2013	SRX	Chassis	Parking Brake Control Module																																																											
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2013	SRX	Chassis	Suspension Control Module																																																											
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2013	SRX	Body	Passenger Presence Module																																																											
N	2013	SRX	Body	Instrument Cluster																																																											
N	2013	SRX	Body	Radio/HVAC Control																																																											
N	2013	SRX	Body	Active Safety Control Module																																																											
N	2013	SRX	Body	Headlamp Control Module																																																											
N	2013	SRX	Body	Trailer Interface Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
N	2013	SRX	Body	Radio																																																								
N	2013	SRX	Body	Amplifier																																																								
N	2013	SRX	Body	Media Disc Player																																																								
N	2013	SRX	Body	Human Machine Interface Control Module																																																								
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																																								
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																																								
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																								
N	2013	SRX	Body	Liftgate Control Module																																																								
N	2013	SRX	Body	Seat Memory Control Module																																																								
N	2013	SRX	Body	Rear Seat Heating Control Module																																																								
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																								
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																								
N	2013	SRX	Body	Right Side Object Detection Control Module																																																								
N	2013	SRX	Body	Left Side Object Detection Control Module																																																								
N	2013	SRX	Body	Parking Assist Control Module																																																								
N	2013	SRX	Body	Frontview Camera Module																																																								
N	2013	SRX	Body	Steering Column Lock Control Module																																																								
N	2013	SRX	Body	Long Range Radar Sensor Module																																																								
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																								
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																								
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																								
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																								
N	2014	SRX	Chassis	Electronic Brake Control Module																																																								
N	2014	SRX	Chassis	Parking Brake Control Module																																																								
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																								
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																																								
N	2014	SRX	Chassis	Suspension Control Module																																																								
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																								
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																								
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
N	2014	SRX	Body	Passenger Presence Module																																																								
N	2014	SRX	Body	Instrument Cluster																																																								
N	2014	SRX	Body	Radio/HVAC Control																																																								
N	2014	SRX	Body	Active Safety Control Module																																																								
N	2014	SRX	Body	Headlamp Control Module																																																								
N	2014	SRX	Body	Trailer Interface Control Module																																																								
N	2014	SRX	Body	Radio																																																								
N	2014	SRX	Body	Amplifier																																																								
N	2014	SRX	Body	Media Disc Player																																																								
N	2014	SRX	Body	Human Machine Interface Control Module																																																								
N	2014	SRX	Body	Navigation Control Module																																																								
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																								
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																																								
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																								
N	2014	SRX	Body	Liftgate Control Module																																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																											
N	2014	SRX	Body	Rear Seat Heating Control Module																																																												
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2014	SRX	Body	Right Side Object Detection Control Module																																																											
N	2014	SRX	Body	Left Side Object Detection Control Module																																																											
N	2014	SRX	Body	Parking Assist Control Module																																																											
N	2014	SRX	Body	Frontview Camera Module																																																											
N	2014	SRX	Body	Steering Column Lock Control Module																																																											
N	2014	SRX	Body	Long Range Radar Sensor Module																																																											
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																											
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2015	SRX	Chassis	Electronic Brake Control Module																																																											
N	2015	SRX	Chassis	Parking Brake Control Module																																																											
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2015	SRX	Chassis	Suspension Control Module																																																											
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2015	SRX	Body	Passenger Presence Module																																																											
N	2015	SRX	Body	Instrument Cluster																																																											
N	2015	SRX	Body	Radio/HVAC Control																																																											
N	2015	SRX	Body	Active Safety Control Module																																																											
N	2015	SRX	Body	Headlamp Control Module																																																											
N	2015	SRX	Body	Trailer Interface Control Module																																																											
N	2015	SRX	Body	Radio																																																											
N	2015	SRX	Body	Amplifier																																																											
N	2015	SRX	Body	Rear Audio Control Module																																																											
N	2015	SRX	Body	Media Disc Player																																																											
N	2015	SRX	Body	Human Machine Interface Control Module																																																											
N	2015	SRX	Body	Navigation Control Module																																																											
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																											
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
N	2015	SRX	Body	Liftgate Control Module																																																											
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																											
N	2015	SRX	Body	Rear Seat Heating Control Module																																																											
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2015	SRX	Body	Right Side Object Detection Control Module																																																											
N	2015	SRX	Body	Left Side Object Detection Control Module																																																											
N	2015	SRX	Body	Parking Assist Control Module																																																											
N	2015	SRX	Body	Frontview Camera Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
N	2015	SRX	Body	Steering Column Lock Control Module																																																											
N	2015	SRX	Body	Long Range Radar Sensor Module																																																											
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																											
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																											
N	2016	SRX	Chassis	Electronic Brake Control Module																																																											
N	2016	SRX	Chassis	Parking Brake Control Module																																																											
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																											
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																																											
N	2016	SRX	Chassis	Suspension Control Module																																																											
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																											
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																											
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
N	2016	SRX	Body	Passenger Presence Module																																																											
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																											
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																																											
N	2016	SRX	Body	Radio/HVAC Control																																																											
N	2016	SRX	Body	Active Safety Control Module																																																											
N	2016	SRX	Body	Headlamp Control Module																																																											
N	2016	SRX	Body	Trailer Interface Control Module																																																											
N	2016	SRX	Body	Radio																																																											
N	2016	SRX	Body	Amplifier																																																										
N	2016	SRX	Body	Rear Audio Control Module																																																											
N	2016	SRX	Body	Media Disc Player																																																											
N	2016	SRX	Body	Human Machine Interface Control Module																																																											
N	2016	SRX	Body	Navigation Control Module																																																											
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																											
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																																											
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																											
N	2016	SRX	Body	Liftgate Control Module																																																											
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																											
N	2016	SRX	Body	Rear Seat Heating Control Module																																																											
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																											
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																											
N	2016	SRX	Body	Right Side Object Detection Control Module																																																											
N	2016	SRX	Body	Left Side Object Detection Control Module																																																											
N	2016	SRX	Body	Parking Assist Control Module																																																											
N	2016	SRX	Body	Frontview Camera Module																																																											
N	2016	SRX	Body	Steering Column Lock Control Module																																																											
N	2016	SRX	Body	Long Range Radar Sensor Module																																																											
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																											
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																											
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																											
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																																
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																															
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
3	2011	ALL	Chassis	Electronic Brake Control Module					V																																																						
3	2011	ALL	Chassis	Electronic Suspension Control																																																											
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																											
3	2011	ALL	Body	Amplifier (Bose)																																																											
3	2011	ALL	Body	Assist Step Controller																																																											
3	2011	ALL	Body	Body Control Module																																																											
3	2011	ALL	Body	Body Control Module (aux.)																																																											
3	2011	ALL	Body	Digital Radio Receiver																																																											
3	2011	ALL	Body	Driver Door Switch																																																											
3	2011	ALL	Body	HVAC Control Module						V																																																					
3	2011	ALL	Body	Inside Rear View Mirror Module																																																											
3	2011	ALL	Body	Instrument Panel Cluster																																																											
3	2011	ALL	Body	Left Side Object Detection Module																																																											
3	2011	ALL	Body	Lift Gate Module																																																											
3	2011	ALL	Body	Memory Seat Module							V																																																				
3	2011	ALL	Body	Park Assist Module																																																											
3	2011	ALL	Body	Passenger Door Switch																																																											
3	2011	ALL	Body	Passenger Presence System																																																											
3	2011	ALL	Body	Radio																																																											
3	2011	ALL	Body	Rear Heated Seat Module																																																											
3	2011	ALL	Body	Rear HVAC/RSA																																																											
3	2011	ALL	Body	Right Side Object Detection Module																																																											
3	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
3	2011	ALL	Body	Theft Deterrent Module																																																											
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																																
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module									V	V	V																																																
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
3	2012	ALL	Chassis	Electronic Brake Control Module					V																																																						
3	2012	ALL	Chassis	Electronic Suspension Control																																																											
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																											
3	2012	ALL	Body	Amplifier (Bose)																																																											
3	2012	ALL	Body	Assist Step Controller																																																											
3	2012	ALL	Body	Body Control Module																																																											
3	2012	ALL	Body	Body Control Module (aux.)																																																											
3	2012	ALL	Body	Driver Door Switch																																																											
3	2012	ALL	Body	HVAC Control Module						V																																																					
3	2012	ALL	Body	Inside Rear View Mirror Module																																																											
3	2012	ALL	Body	Instrument Panel Cluster																																																											
3	2012	ALL	Body	Left Side Object Detection Module																																																											
3	2012	ALL	Body	Lift Gate Module																																																											
3	2012	ALL	Body	Memory Seat Module							V																																																				
3	2012	ALL	Body	Park Assist Module																																																											
3	2012	ALL	Body	Passenger Door Switch																																																											
3	2012	ALL	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
3	2012	ALL	Body	Radio																																																											
3	2012	ALL	Body	Rear Heated Seat Module																																																											
3	2012	ALL	Body	Rear HVAC/RSA																																																											
3	2012	ALL	Body	Right Side Object Detection Module																																																											
3	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
3	2012	ALL	Body	Theft Deterrent Module																																																											
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																																
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
3	2013	ALL	Chassis	Electronic Brake Control Module					V																																																						
3	2013	ALL	Chassis	Electronic Suspension Control																																																											
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																											
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																											
3	2013	ALL	Body	Amplifier (Bose)																																																											
3	2013	ALL	Body	Assist Step Controller																																																											
3	2013	ALL	Body	Body Control Module																																																											
3	2013	ALL	Body	Body Control Module (aux.)																																																											
3	2013	ALL	Body	Driver Door Switch																																																											
3	2013	ALL	Body	HVAC Control Module						V																																																					
3	2013	ALL	Body	Inside Rear View Mirror Module																																																											
3	2013	ALL	Body	Instrument Panel Cluster																																																											
3	2013	ALL	Body	Left Side Object Detection Module																																																											
3	2013	ALL	Body	Lift Gate Module																																																											
3	2013	ALL	Body	Memory Seat Module							V																																																				
3	2013	ALL	Body	Park Assist Module																																																											
3	2013	ALL	Body	Passenger Door Switch																																																											
3	2013	ALL	Body	Passenger Presence System																																																											
3	2013	ALL	Body	Radio																																																											
3	2013	ALL	Body	Rear Heated Seat Module																																																											
3	2013	ALL	Body	Rear HVAC/RSA																																																											
3	2013	ALL	Body	Right Side Object Detection Module																																																											
3	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
3	2013	ALL	Body	Theft Deterrent Module																																																											
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																											
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																											
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																											
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																								V																																			
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																											
3	2014	Escalade	Chassis	Suspension Control Module																																																											
3	2014	Escalade	Body	Body Control Module																																																											
3	2014	Escalade	Body	Auxiliary Body Control Module																																																											
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
3	2014	Escalade	Body	Passenger Presence Module																																																											
3	2014	Escalade	Body	Instrument Cluster																																																											
3	2014	Escalade	Body	Radio																																																											
3	2014	Escalade	Body	Amplifier																																																											
3	2014	Escalade	Body	Rear Audio Control Module																																																											
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																											
3	2014	Escalade	Body	Personal Audio Link Control Module																																																											
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																											
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
3	2014	Escalade	Body	HVAC Control Module																																																										
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																										
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																										
3	2014	Escalade	Body	Liftgate Control Module																																																										
3	2014	Escalade	Body	Seat Memory Control Module																																																										
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																										
3	2014	Escalade	Body	Assist Step Control Module																								V																																		
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																										
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																										
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																										
3	2014	Escalade	Body	Parking Assist Control Module																									V																																	
3	2014	Escalade	Body	Theft Deterrent Module																																																										
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																										
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																							V																																			
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2014	Escalade ESV	Body	Body Control Module																																																										
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																										
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2014	Escalade ESV	Body	Passenger Presence Module																																																										
3	2014	Escalade ESV	Body	Instrument Cluster																																																										
3	2014	Escalade ESV	Body	Radio																																																										
3	2014	Escalade ESV	Body	Amplifier																																																										
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																										
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																										
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																										
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																										
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2014	Escalade ESV	Body	HVAC Control Module																																																										
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																										
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																										
3	2014	Escalade ESV	Body	Liftgate Control Module																																																										
3	2014	Escalade ESV	Body	Seat Memory Control Module																																																										
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																										
3	2014	Escalade ESV	Body	Assist Step Control Module																								V																																		
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																										
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																										
3	2014	Escalade ESV	Body	Parking Assist Control Module																									V																																	
3	2014	Escalade ESV	Body	Theft Deterrent Module																																																										
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																															
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																										
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																							V					V																														
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																										
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																														V																												
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																														V																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																										
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																										
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																										
3	2015	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2015	Escalade	Chassis	Parking Brake Control Module																																																										
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2015	Escalade	Chassis	Power Steering Control Module																														V	V																											
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2015	Escalade	Chassis	Suspension Control Module																																																										
3	2015	Escalade	Body	Body Control Module																																																										
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2015	Escalade	Body	Passenger Presence Module																																																										
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2015	Escalade	Body	Instrument Cluster																																																										
3	2015	Escalade	Body	Radio/HVAC Control																																																										
3	2015	Escalade	Body	Active Safety Control Module																																																										
3	2015	Escalade	Body	Video Processing Control Module																																																										
3	2015	Escalade	Body	Radio																																																										
3	2015	Escalade	Body	Amplifier																																																										
3	2015	Escalade	Body	Media Disc Player																																																										
3	2015	Escalade	Body	Human Machine Interface Control Module																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																										
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2015	Escalade	Body	HVAC Control Module																																																										
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																										
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																										
3	2015	Escalade	Body	Keyless Entry Control Module																																																										
3	2015	Escalade	Body	Assist Step Control Module																																																										
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																										
3	2015	Escalade	Body	Parking Assist Control Module																																																										
3	2015	Escalade	Body	Frontview Camera Module																																																										
3	2015	Escalade	Body	Steering Column Lock Control Module																																																										
3	2015	Escalade	Body	Battery Energy Control Module																																																										
3	2015	Escalade	Body	Long Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																															
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																										
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																							V					V																														
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																														V																												
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																														V																												
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																														V																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																										
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Power Steering Control Module																														V	V																												
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2015	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2015	Escalade ESV	Body	Body Control Module																																																										
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2015	Escalade ESV	Body	Passenger Presence Module																																																										
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2015	Escalade ESV	Body	Instrument Cluster																																																										
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																										
3	2015	Escalade ESV	Body	Active Safety Control Module																																																										
3	2015	Escalade ESV	Body	Video Processing Control Module																																																										
3	2015	Escalade ESV	Body	Radio																																																										
3	2015	Escalade ESV	Body	Amplifier																																																										
3	2015	Escalade ESV	Body	Media Disc Player																																																										
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																										
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
3	2015	Escalade ESV	Body	HVAC Control Module																																																										
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																										
3	2015	Escalade ESV	Body	Assist Step Control Module																																																										
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2015	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2015	Escalade ESV	Body	Frontview Camera Module																																																										
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																										
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
3	2016	Escalade	Chassis	Electronic Brake Control Module																																																										
3	2016	Escalade	Chassis	Parking Brake Control Module																																																										
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2016	Escalade	Chassis	Power Steering Control Module																														V	V																												
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2016	Escalade	Chassis	Suspension Control Module																																																										
3	2016	Escalade	Body	Body Control Module																																																										
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
3	2016	Escalade	Body	Passenger Presence Module																																																										
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2016	Escalade	Body	Instrument Cluster																																																										
3	2016	Escalade	Body	Radio/HVAC Control																																																										
3	2016	Escalade	Body	Active Safety Control Module																																																										
3	2016	Escalade	Body	Video Processing Control Module																																																										
3	2016	Escalade	Body	Radio																																																										
3	2016	Escalade	Body	Amplifier																																																										
3	2016	Escalade	Body	Media Disc Player																																																										
3	2016	Escalade	Body	Human Machine Interface Control Module																																																										
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																																										
3	2016	Escalade	Body	HVAC Control Module																																																										
3	2016	Escalade	Body	Liftgate Control Module																																																										
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																										
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																										
3	2016	Escalade	Body	Keyless Entry Control Module																																																										
3	2016	Escalade	Body	Assist Step Control Module																																																										
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																										
3	2016	Escalade	Body	Parking Assist Control Module																																																										
3	2016	Escalade	Body	Frontview Camera Module																																																										
3	2016	Escalade	Body	Steering Column Lock Control Module																																																										
3	2016	Escalade	Body	Long Range Radar Sensor Module																																																										
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																														V																												
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																														V																												
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																										
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
3	2016	Escalade ESV	Chassis	Power Steering Control Module																															V	V																										
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
3	2016	Escalade ESV	Chassis	Suspension Control Module																																																										
3	2016	Escalade ESV	Body	Body Control Module																																																										
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
3	2016	Escalade ESV	Body	Passenger Presence Module																																																										
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
3	2016	Escalade ESV	Body	Instrument Cluster																																																										
3	2016	Escalade ESV	Body	Radio Control																																																										
3	2016	Escalade ESV	Body	HVAC Control																																																										
3	2016	Escalade ESV	Body	Active Safety Control Module																																																										
3	2016	Escalade ESV	Body	Video Processing Control Module																																																										
3	2016	Escalade ESV	Body	Radio																																																										
3	2016	Escalade ESV	Body	Amplifier																																																										
3	2016	Escalade ESV	Body	Media Disc Player																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																										
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																										
3	2016	Escalade ESV	Body	HVAC Control Module																																																										
3	2016	Escalade ESV	Body	Liftgate Control Module																																																										
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																										
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																										
3	2016	Escalade ESV	Body	Assist Step Control Module																																																										
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																										
3	2016	Escalade ESV	Body	Frontview Camera Module																																																										
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																										
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																															
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																														
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
4	2011	ALL	Chassis	Electronic Brake Control Module					V																																																					
4	2011	ALL	Chassis	Electronic Suspension Control																																																										
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																										
4	2011	ALL	Body	Amplifier (Bose)																																																										
4	2011	ALL	Body	Assist Step Controller																																																										
4	2011	ALL	Body	Body Control Module																																																										
4	2011	ALL	Body	Body Control Module (aux.)																																																										
4	2011	ALL	Body	Driver Door Switch																																																										
4	2011	ALL	Body	HVAC Control Module						V																																																				
4	2011	ALL	Body	Inside Rear View Mirror Module																																																										
4	2011	ALL	Body	Instrument Panel Cluster																																																										
4	2011	ALL	Body	Left Side Object Detection Module																																																										
4	2011	ALL	Body	Lift Gate Module																																																										
4	2011	ALL	Body	Memory Seat Module							V																																																			
4	2011	ALL	Body	Park Assist Module																																																										
4	2011	ALL	Body	Passenger Door Switch																																																										
4	2011	ALL	Body	Passenger Presence System																																																										
4	2011	ALL	Body	Radio																																																										
4	2011	ALL	Body	Rear Heated Seat Module																																																										
4	2011	ALL	Body	Rear HVAC/RSA																																																										
4	2011	ALL	Body	Right Side Object Detection Module																																																										
4	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
4	2011	ALL	Body	Theft Deterrent Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																															
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module									V	V	V																																															
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
4	2012	ALL	Chassis	Electronic Brake Control Module					V																																																						
4	2012	ALL	Chassis	Electronic Suspension Control																																																											
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																										
4	2012	ALL	Body	Amplifier (Bose)																																																										
4	2012	ALL	Body	Assist Step Controller																																																										
4	2012	ALL	Body	Body Control Module																																																										
4	2012	ALL	Body	Body Control Module (aux.)																																																										
4	2012	ALL	Body	Driver Door Switch																																																										
4	2012	ALL	Body	HVAC Control Module						V																																																				
4	2012	ALL	Body	Inside Rear View Mirror Module																																																										
4	2012	ALL	Body	Instrument Panel Cluster																																																										
4	2012	ALL	Body	Left Side Object Detection Module																																																										
4	2012	ALL	Body	Lift Gate Module																																																										
4	2012	ALL	Body	Memory Seat Module							V																																																			
4	2012	ALL	Body	Park Assist Module																																																										
4	2012	ALL	Body	Passenger Door Switch																																																										
4	2012	ALL	Body	Passenger Presence System																																																										
4	2012	ALL	Body	Radio																																																										
4	2012	ALL	Body	Rear Heated Seat Module																																																										
4	2012	ALL	Body	Rear HVAC/RSA																																																										
4	2012	ALL	Body	Right Side Object Detection Module																																																										
4	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
4	2012	ALL	Body	Theft Deterrent Module																																																										
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																																
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
4	2013	ALL	Chassis	Electronic Brake Control Module					V																																																						
4	2013	ALL	Chassis	Electronic Suspension Control																																																										
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																										
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																										
4	2013	ALL	Body	Amplifier (Bose)																																																										
4	2013	ALL	Body	Assist Step Controller																																																										
4	2013	ALL	Body	Body Control Module																																																										
4	2013	ALL	Body	Body Control Module (aux.)																																																										
4	2013	ALL	Body	Driver Door Switch																																																										
4	2013	ALL	Body	HVAC Control Module						V																																																				
4	2013	ALL	Body	Inside Rear View Mirror Module																																																										
4	2013	ALL	Body	Instrument Panel Cluster																																																										
4	2013	ALL	Body	Left Side Object Detection Module																																																										
4	2013	ALL	Body	Lift Gate Module																																																										
4	2013	ALL	Body	Memory Seat Module							V																																																			
4	2013	ALL	Body	Park Assist Module																																																										
4	2013	ALL	Body	Passenger Door Switch																																																										
4	2013	ALL	Body	Passenger Presence System																																																										
4	2013	ALL	Body	Radio																																																										
4	2013	ALL	Body	Rear Heated Seat Module																																																										
4	2013	ALL	Body	Rear HVAC/RSA																																																										
4	2013	ALL	Body	Right Side Object Detection Module																																																										
4	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
4	2013	ALL	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																														
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																														
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																														
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																							V																																							
4	2014	Escalade	Chassis	Electronic Brake Control Module																																																														
4	2014	Escalade	Chassis	Suspension Control Module																																																														
4	2014	Escalade	Body	Body Control Module																																																														
4	2014	Escalade	Body	Auxiliary Body Control Module																																																														
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
4	2014	Escalade	Body	Passenger Presence Module																																																														
4	2014	Escalade	Body	Instrument Cluster																																																														
4	2014	Escalade	Body	Radio																																																														
4	2014	Escalade	Body	Amplifier																																																														
4	2014	Escalade	Body	Rear Audio Control Module																																																														
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																																														
4	2014	Escalade	Body	Personal Audio Link Control Module																																																														
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																														
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																														
4	2014	Escalade	Body	HVAC Control Module																																																														
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																														
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																														
4	2014	Escalade	Body	Liftgate Control Module																																																														
4	2014	Escalade	Body	Seat Memory Control Module																																																														
4	2014	Escalade	Body	Rear Seat Heating Control Module																																																														
4	2014	Escalade	Body	Assist Step Control Module																								V																																							
4	2014	Escalade	Body	Right Side Object Detection Control Module																																																														
4	2014	Escalade	Body	Left Side Object Detection Control Module																																																														
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																																														
4	2014	Escalade	Body	Parking Assist Control Module																									V																																					
4	2014	Escalade	Body	Theft Deterrent Module																																																														
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																														
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																														
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																														
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																							V																																							
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																														
4	2014	Escalade ESV	Chassis	Suspension Control Module																																																														
4	2014	Escalade ESV	Body	Body Control Module																																																														
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																														
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
4	2014	Escalade ESV	Body	Passenger Presence Module																																																														
4	2014	Escalade ESV	Body	Instrument Cluster																																																														
4	2014	Escalade ESV	Body	Radio																																																														
4	2014	Escalade ESV	Body	Amplifier																																																														
4	2014	Escalade ESV	Body	Rear Audio Control Module																																																														
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																														
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																														
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																														
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																														
4	2014	Escalade ESV	Body	HVAC Control Module																																																														
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																														
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																														

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
4	2014	Escalade ESV	Body	Liftgate Control Module																																																														
4	2014	Escalade ESV	Body	Seat Memory Control Module																																																														
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																														
4	2014	Escalade ESV	Body	Assist Step Control Module																								V																																						
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																														
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																														
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																														
4	2014	Escalade ESV	Body	Parking Assist Control Module																									V																																				
4	2014	Escalade ESV	Body	Theft Deterrent Module																																																														
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																														
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																														
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																		
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																														
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																							V					V																																		
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																														
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																																	
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																																	
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																														
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																														
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																														
4	2015	Escalade	Chassis	Electronic Brake Control Module																																																														
4	2015	Escalade	Chassis	Parking Brake Control Module																																																														
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																														
4	2015	Escalade	Chassis	Power Steering Control Module																														V	V																														
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																														
4	2015	Escalade	Chassis	Suspension Control Module																																																														
4	2015	Escalade	Body	Body Control Module																																																														
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
4	2015	Escalade	Body	Passenger Presence Module																																																														
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																														
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																														
4	2015	Escalade	Body	Instrument Cluster																																																														
4	2015	Escalade	Body	Radio/HVAC Control																																																														
4	2015	Escalade	Body	Active Safety Control Module																																																														
4	2015	Escalade	Body	Video Processing Control Module																																																														
4	2015	Escalade	Body	Radio																																																														
4	2015	Escalade	Body	Amplifier																																																														
4	2015	Escalade	Body	Media Disc Player																																																														
4	2015	Escalade	Body	Human Machine Interface Control Module																																																														
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																														
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																														
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																														
4	2015	Escalade	Body	HVAC Control Module																																																														
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																														
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																														
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																														
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																														
4	2015	Escalade	Body	Keyless Entry Control Module																																																														
4	2015	Escalade	Body	Assist Step Control Module																																																														
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																														

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
4	2015	Escalade	Body	Parking Assist Control Module																																																										
4	2015	Escalade	Body	Frontview Camera Module																																																										
4	2015	Escalade	Body	Steering Column Lock Control Module																																																										
4	2015	Escalade	Body	Battery Energy Control Module																																																										
4	2015	Escalade	Body	Long Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																															
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																										
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																							V					V																														
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																													V																													
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																													V																													
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																										
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																										
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2015	Escalade ESV	Chassis	Power Steering Control Module																														V	V																											
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2015	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2015	Escalade ESV	Body	Body Control Module																																																										
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2015	Escalade ESV	Body	Passenger Presence Module																																																										
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2015	Escalade ESV	Body	Instrument Cluster																																																										
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																										
4	2015	Escalade ESV	Body	Active Safety Control Module																																																										
4	2015	Escalade ESV	Body	Video Processing Control Module																																																										
4	2015	Escalade ESV	Body	Radio																																																										
4	2015	Escalade ESV	Body	Amplifier																																																										
4	2015	Escalade ESV	Body	Media Disc Player																																																										
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																										
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																										
4	2015	Escalade ESV	Body	HVAC Control Module																																																										
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																										
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																										
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																										
4	2015	Escalade ESV	Body	Assist Step Control Module																																																										
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
4	2015	Escalade ESV	Body	Parking Assist Control Module																																																										
4	2015	Escalade ESV	Body	Frontview Camera Module																																																										
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
4	2016	Escalade	Chassis	Electronic Brake Control Module																																																										
4	2016	Escalade	Chassis	Parking Brake Control Module																																																										
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2016	Escalade	Chassis	Power Steering Control Module																														V	V																											
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2016	Escalade	Chassis	Suspension Control Module																																																										
4	2016	Escalade	Body	Body Control Module																																																										
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2016	Escalade	Body	Passenger Presence Module																																																										
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2016	Escalade	Body	Instrument Cluster																																																										
4	2016	Escalade	Body	Radio/HVAC Control																																																										
4	2016	Escalade	Body	Active Safety Control Module																																																										
4	2016	Escalade	Body	Video Processing Control Module																																																										
4	2016	Escalade	Body	Radio																																																										
4	2016	Escalade	Body	Amplifier																																																										
4	2016	Escalade	Body	Media Disc Player																																																										
4	2016	Escalade	Body	Human Machine Interface Control Module																																																										
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																																										
4	2016	Escalade	Body	HVAC Control Module																																																										
4	2016	Escalade	Body	Liftgate Control Module																																																										
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																										
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																										
4	2016	Escalade	Body	Keyless Entry Control Module																																																										
4	2016	Escalade	Body	Assist Step Control Module																																																										
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																										
4	2016	Escalade	Body	Parking Assist Control Module																																																										
4	2016	Escalade	Body	Frontview Camera Module																																																										
4	2016	Escalade	Body	Steering Column Lock Control Module																																																										
4	2016	Escalade	Body	Long Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																										
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																										
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																										
4	2016	Escalade ESV	Chassis	Power Steering Control Module																														V	V																											
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																										
4	2016	Escalade ESV	Chassis	Suspension Control Module																																																										
4	2016	Escalade ESV	Body	Body Control Module																																																										
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
4	2016	Escalade ESV	Body	Passenger Presence Module																																																										
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																										
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																										
4	2016	Escalade ESV	Body	Instrument Cluster																																																										
4	2016	Escalade ESV	Body	Radio Control																																																										
4	2016	Escalade ESV	Body	HVAC Control																																																										
4	2016	Escalade ESV	Body	Active Safety Control Module																																																										
4	2016	Escalade ESV	Body	Video Processing Control Module																																																										
4	2016	Escalade ESV	Body	Radio																																																										
4	2016	Escalade ESV	Body	Amplifier																																																										
4	2016	Escalade ESV	Body	Media Disc Player																																																										
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																										
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																										
4	2016	Escalade ESV	Body	HVAC Control Module																																																										
4	2016	Escalade ESV	Body	Liftgate Control Module																																																										
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																										
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																										
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																										
4	2016	Escalade ESV	Body	Assist Step Control Module																																																										
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																										
4	2016	Escalade ESV	Body	Parking Assist Control Module																																																										
4	2016	Escalade ESV	Body	Frontview Camera Module																																																										
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																										
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																										
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																										
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																										
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																										
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																										
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																										
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																										
ALL	2004	Hearse	Chassis	DRP/ABS/TCS																																																										
ALL	2004	Hearse	Chassis	Magna Steer																																																										
ALL	2004	Hearse	Chassis	Rear Integration Module																																																										
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																										
ALL	2004	Hearse	Body	Amplifier (Delco)																																																										
ALL	2004	Hearse	Body	Dash Integration Module																																																										
ALL	2004	Hearse	Body	Driver Door Switch																																																										
ALL	2004	Hearse	Body	Driver Door Module																																																										
ALL	2004	Hearse	Body	Passenger Door Module																																																										
ALL	2004	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2004	Hearse	Body	Instrument Panel Module																																																										
ALL	2004	Hearse	Body	Personalization																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
ALL	2004	Hearse	Body	Radio																																																										
ALL	2004	Hearse	Body	Rear Integration Module																																																										
ALL	2004	Hearse	Body	Remote Function Actuation																																																										
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																																										
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																										
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																										
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																										
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																										
ALL	2004	Limousine	Chassis	DRP/ABS/TCS																																																										
ALL	2004	Limousine	Chassis	Magna Steer																																																										
ALL	2004	Limousine	Chassis	Rear Integration Module																																																										
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																										
ALL	2004	Limousine	Body	Amplifier (Delco)																																																										
ALL	2004	Limousine	Body	Dash Integration Module																																																										
ALL	2004	Limousine	Body	Driver Door Switch																																																										
ALL	2004	Limousine	Body	Driver Door Module																																																										
ALL	2004	Limousine	Body	Passenger Door Module																																																										
ALL	2004	Limousine	Body	Left Mid Door Module																																																										
ALL	2004	Limousine	Body	Left Rear Door Module																																																										
ALL	2004	Limousine	Body	Right Mid Door Module																																																										
ALL	2004	Limousine	Body	Right Rear Door Module																																																										
ALL	2004	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2004	Limousine	Body	Instrument Panel Module																																																										
ALL	2004	Limousine	Body	Memory Seat Module																																																										
ALL	2004	Limousine	Body	Navigation Radio																																																										
ALL	2004	Limousine	Body	Personalization																																																										
ALL	2004	Limousine	Body	Radio																																																										
ALL	2004	Limousine	Body	Rear Climate Control Panel																																																										
ALL	2004	Limousine	Body	Rear Integration Module																																																										
ALL	2004	Limousine	Body	Remote Function Actuation																																																										
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																																										
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																										
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																										
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																										
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																										
ALL	2005	Hearse	Chassis	DRP/ABS/TCS																																																										
ALL	2005	Hearse	Chassis	Magna Steer																																																										
ALL	2005	Hearse	Chassis	Rear Integration Module																																																										
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																										
ALL	2005	Hearse	Body	Amplifier (Delco)																																																										
ALL	2005	Hearse	Body	Dash Integration Module																																																										
ALL	2005	Hearse	Body	Driver Door Switch																																																										
ALL	2005	Hearse	Body	Driver Door Module																																																										
ALL	2005	Hearse	Body	Passenger Door Module																																																										
ALL	2005	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2005	Hearse	Body	Instrument Panel Module																																																										
ALL	2005	Hearse	Body	Personalization																																																										
ALL	2005	Hearse	Body	Radio																																																										
ALL	2005	Hearse	Body	Rear Integration Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
ALL	2005	Hearse	Body	Remote Function Actuation																																																												
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																																												
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																												
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																												
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																												
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																												
ALL	2005	Limousine	Chassis	DRP/ABS/TCS																																																												
ALL	2005	Limousine	Chassis	Magna Steer																																																												
ALL	2005	Limousine	Chassis	Rear Integration Module																																																												
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																												
ALL	2005	Limousine	Body	Amplifier (Delco)																																																												
ALL	2005	Limousine	Body	Dash Integration Module																																																												
ALL	2005	Limousine	Body	Driver Door Switch																																																												
ALL	2005	Limousine	Body	Driver Door Module																																																												
ALL	2005	Limousine	Body	Passenger Door Module																																																												
ALL	2005	Limousine	Body	Left Mid Door Module																																																												
ALL	2005	Limousine	Body	Left Rear Door Module																																																												
ALL	2005	Limousine	Body	Right Mid Door Module																																																												
ALL	2005	Limousine	Body	Right Rear Door Module																																																												
ALL	2005	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2005	Limousine	Body	Instrument Panel Module																																																												
ALL	2005	Limousine	Body	Memory Seat Module																																																												
ALL	2005	Limousine	Body	Navigation Radio																																																												
ALL	2005	Limousine	Body	Personalization																																																												
ALL	2005	Limousine	Body	Radio																																																												
ALL	2005	Limousine	Body	Rear Climate Control Panel																																																												
ALL	2005	Limousine	Body	Rear Integration Module																																																												
ALL	2005	Limousine	Body	Remote Function Actuation																																																												
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																																												
ALL	2006	Hearse	Powertrain	Engine Control Module																																																												
ALL	2006	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2006	Hearse	Body	Amplifier (Bose)																																																												
ALL	2006	Hearse	Body	Body Control Module																																																												
ALL	2006	Hearse	Body	Digital Radio Receiver																																																												
ALL	2006	Hearse	Body	Driver Door Switch																																																												
ALL	2006	Hearse	Body	Driver Position Module																																																												
ALL	2006	Hearse	Body	HVAC Control Module																																																												
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																												
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2006	Hearse	Body	Passenger Door Switch																																																												
ALL	2006	Hearse	Body	Passenger Presence System																																																												
ALL	2006	Hearse	Body	Radio																																																												
ALL	2006	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																												
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2006	Hearse	Body	Theft Deterrent Module																																																												
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
ALL	2006	Limousine	Powertrain	Engine Control Module																																																											
ALL	2006	Limousine	Powertrain	Transmission Control Module																																																											
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																																											
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																											
ALL	2006	Limousine	Body	Amplifier (Bose)																																																											
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																											
ALL	2006	Limousine	Body	Body Control Module																																																											
ALL	2006	Limousine	Body	Digital Radio Receiver																																																											
ALL	2006	Limousine	Body	Driver Door Switch																																																											
ALL	2006	Limousine	Body	Driver Position Module																																																											
ALL	2006	Limousine	Body	HVAC Control Module																																																											
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																											
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2006	Limousine	Body	Passenger Door Switch																																																											
ALL	2006	Limousine	Body	Passenger Presence System																																																											
ALL	2006	Limousine	Body	Radio																																																											
ALL	2006	Limousine	Body	Rear Heated Seat Module																																																											
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																											
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																																											
ALL	2006	Limousine	Body	Theft Deterrent Module																																																											
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																																											
ALL	2007	Hearse	Powertrain	Engine Control Module																																																											
ALL	2007	Hearse	Powertrain	Transmission Control Module																																																											
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																											
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																																											
ALL	2007	Hearse	Body	Amplifier (Bose)																																																											
ALL	2007	Hearse	Body	Body Control Module																																																											
ALL	2007	Hearse	Body	Digital Radio Receiver																																																											
ALL	2007	Hearse	Body	Driver Door Switch																																																											
ALL	2007	Hearse	Body	Driver Position Module																																																											
ALL	2007	Hearse	Body	HVAC Control Module																																																											
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																											
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																											
ALL	2007	Hearse	Body	Passenger Door Switch																																																											
ALL	2007	Hearse	Body	Passenger Presence System																																																											
ALL	2007	Hearse	Body	Radio																																																											
ALL	2007	Hearse	Body	Rear Heated Seat Module																																																											
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																																											
ALL	2007	Hearse	Body	Theft Deterrent Module																																																											
ALL	2007	Limousine	Powertrain	Engine Control Module																																																											
ALL	2007	Limousine	Powertrain	Transmission Control Module																																																											
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																											
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																																											
ALL	2007	Limousine	Body	Amplifier (Bose)																																																											
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																																											
ALL	2007	Limousine	Body	Body Control Module																																																											
ALL	2007	Limousine	Body	Digital Radio Receiver																																																											
ALL	2007	Limousine	Body	Driver Door Switch																																																											
ALL	2007	Limousine	Body	Driver Position Module																																																											
ALL	2007	Limousine	Body	HVAC Control Module																																																											
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2007	Limousine	Body	Passenger Door Switch																																																											
ALL	2007	Limousine	Body	Passenger Presence System																																																											
ALL	2007	Limousine	Body	Radio																																																											
ALL	2007	Limousine	Body	Rear Heated Seat Module																																																											
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																																											
ALL	2007	Limousine	Body	Theft Deterrent Module																																																											
ALL	2008	Hearse	Powertrain	Engine Control Module																																																											
ALL	2008	Hearse	Powertrain	Transmission Control Module																																																											
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																											
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																																											
ALL	2008	Hearse	Body	Amplifier (Bose)																																																											
ALL	2008	Hearse	Body	Body Control Module																																																											
ALL	2008	Hearse	Body	Climate Control Seat Module																																																											
ALL	2008	Hearse	Body	Digital Radio Receiver																																																											
ALL	2008	Hearse	Body	Driver Door Switch																																																											
ALL	2008	Hearse	Body	Driver Position Module																																																											
ALL	2008	Hearse	Body	HVAC Control Module																																																											
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																											
ALL	2008	Hearse	Body	Passenger Door Switch																																																											
ALL	2008	Hearse	Body	Passenger Presence System																																																											
ALL	2008	Hearse	Body	Radio																																																											
ALL	2008	Hearse	Body	Rear Heated Seat Module																																																											
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																																											
ALL	2008	Hearse	Body	Theft Deterrent Module																																																											
ALL	2008	Limousine	Powertrain	Engine Control Module																																																											
ALL	2008	Limousine	Powertrain	Transmission Control Module																																																											
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																											
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																																											
ALL	2008	Limousine	Body	Amplifier (Bose)																																																											
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																											
ALL	2008	Limousine	Body	Body Control Module																																																											
ALL	2008	Limousine	Body	Climate Control Seat Module																																																											
ALL	2008	Limousine	Body	Digital Radio Receiver																																																											
ALL	2008	Limousine	Body	Driver Door Switch																																																											
ALL	2008	Limousine	Body	Driver Position Module																																																											
ALL	2008	Limousine	Body	HVAC Control Module																																																											
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																											
ALL	2008	Limousine	Body	Passenger Door Switch																																																											
ALL	2008	Limousine	Body	Passenger Presence System																																																											
ALL	2008	Limousine	Body	Radio																																																											
ALL	2008	Limousine	Body	Rear Heated Seat Module																																																											
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																																											
ALL	2008	Limousine	Body	Theft Deterrent Module																																																											
ALL	2009	Hearse	Powertrain	Engine Control Module																																																											
ALL	2009	Hearse	Powertrain	Transmission Control Module																																																											
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																											
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																																											
ALL	2009	Hearse	Body	Amplifier (Bose)																																																											
ALL	2009	Hearse	Body	Body Control Module																																																											
ALL	2009	Hearse	Body	Climate Control Seat Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
ALL	2009	Hearse	Body	Digital Radio Receiver																																																										
ALL	2009	Hearse	Body	Driver Door Switch																																																										
ALL	2009	Hearse	Body	Driver Position Module																																																										
ALL	2009	Hearse	Body	HVAC Control Module																																																										
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2009	Hearse	Body	Passenger Door Switch																																																										
ALL	2009	Hearse	Body	Passenger Presence System																																																										
ALL	2009	Hearse	Body	Radio																																																										
ALL	2009	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	Hearse	Body	Theft Deterrent Module																																																										
ALL	2009	Limousine	Powertrain	Engine Control Module																																																										
ALL	2009	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2009	Limousine	Body	Amplifier (Bose)																																																										
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2009	Limousine	Body	Body Control Module																																																										
ALL	2009	Limousine	Body	Climate Control Seat Module																																																										
ALL	2009	Limousine	Body	Digital Radio Receiver																																																										
ALL	2009	Limousine	Body	Driver Door Switch																																																										
ALL	2009	Limousine	Body	Driver Position Module																																																										
ALL	2009	Limousine	Body	HVAC Control Module																																																										
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2009	Limousine	Body	Passenger Door Switch																																																										
ALL	2009	Limousine	Body	Passenger Presence System																																																										
ALL	2009	Limousine	Body	Radio																																																										
ALL	2009	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	Limousine	Body	Theft Deterrent Module																																																										
ALL	2010	Hearse	Powertrain	Engine Control Module																																																										
ALL	2010	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2010	Hearse	Body	Amplifier (Bose)																																																										
ALL	2010	Hearse	Body	Body Control Module																																																										
ALL	2010	Hearse	Body	Climate Control Seat Module																																																										
ALL	2010	Hearse	Body	Digital Radio Receiver																																																										
ALL	2010	Hearse	Body	Driver Door Switch																																																										
ALL	2010	Hearse	Body	Driver Position Module																																																										
ALL	2010	Hearse	Body	HVAC Control Module																																																										
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2010	Hearse	Body	Passenger Door Switch																																																										
ALL	2010	Hearse	Body	Passenger Presence System																																																										
ALL	2010	Hearse	Body	Radio																																																										
ALL	2010	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	Hearse	Body	Theft Deterrent Module																																																										
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	Limousine	Powertrain	Engine Control Module																																																										
ALL	2010	Limousine	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																												
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																																												
ALL	2010	Limousine	Body	Amplifier (Bose)																																																												
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																												
ALL	2010	Limousine	Body	Body Control Module																																																												
ALL	2010	Limousine	Body	Climate Control Seat Module																																																												
ALL	2010	Limousine	Body	Digital Radio Receiver																																																												
ALL	2010	Limousine	Body	Driver Door Switch																																																												
ALL	2010	Limousine	Body	Driver Position Module																																																												
ALL	2010	Limousine	Body	HVAC Control Module																																																												
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2010	Limousine	Body	Passenger Door Switch																																																												
ALL	2010	Limousine	Body	Passenger Presence System																																																												
ALL	2010	Limousine	Body	Radio																																																												
ALL	2010	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2010	Limousine	Body	Theft Deterrent Module																																																												
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																																												
ALL	2011	Hearse	Powertrain	Engine Control Module																																																												
ALL	2011	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2011	Hearse	Body	Amplifier (Bose)																																																												
ALL	2011	Hearse	Body	Body Control Module																																																												
ALL	2011	Hearse	Body	Climate Control Seat Module																																																												
ALL	2011	Hearse	Body	Digital Radio Receiver																																																												
ALL	2011	Hearse	Body	Driver Door Switch																																																												
ALL	2011	Hearse	Body	Driver Position Module																																																												
ALL	2011	Hearse	Body	HVAC Control Module																																																												
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2011	Hearse	Body	Passenger Door Switch																																																												
ALL	2011	Hearse	Body	Passenger Presence System																																																												
ALL	2011	Hearse	Body	Radio																																																												
ALL	2011	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2011	Hearse	Body	Theft Deterrent Module																																																												
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																																												
ALL	2011	Limousine	Powertrain	Engine Control Module																																																												
ALL	2011	Limousine	Powertrain	Transmission Control Module																																																												
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																												
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																																												
ALL	2011	Limousine	Body	Amplifier (Bose)																																																												
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																												
ALL	2011	Limousine	Body	Body Control Module																																																												
ALL	2011	Limousine	Body	Climate Control Seat Module																																																												
ALL	2011	Limousine	Body	Digital Radio Receiver																																																												
ALL	2011	Limousine	Body	Driver Door Switch																																																												
ALL	2011	Limousine	Body	Driver Position Module																																																												
ALL	2011	Limousine	Body	HVAC Control Module																																																												
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2011	Limousine	Body	Passenger Door Switch																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
ALL	2011	Limousine	Body	Passenger Presence System																																																															
ALL	2011	Limousine	Body	Radio																																																															
ALL	2011	Limousine	Body	Rear Heated Seat Module																																																															
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																																															
ALL	2011	Limousine	Body	Theft Deterrent Module																																																															
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																																
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																																
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																																
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																																
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																																
C	2004	ALL	Chassis	ESC																																																																
C	2004	ALL	Chassis	Rear Wheel Steering																																																																
C	2004	ALL	Chassis	Tire Pressure Monitor																																																																
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																																
C	2004	ALL	Chassis	VSES																																																																
C	2004	ALL	Body	Amplifier (Bose)																																																																
C	2004	ALL	Body	Body Control Module																																																																
C	2004	ALL	Body	CD Changer																																																																
C	2004	ALL	Body	Chime																																																																
C	2004	ALL	Body	Driver Door Module																																																																
C	2004	ALL	Body	Driver Seat Module																																																																
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																																
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																																
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																																
C	2004	ALL	Body	Instrument Panel Cluster																																																																
C	2004	ALL	Body	OnStar																																																																
C	2004	ALL	Body	Passenger Door Module																																																																
C	2004	ALL	Body	Passenger Presence System																																																																
C	2004	ALL	Body	Base Radio																																																																
C	2004	ALL	Body	Uplevel Radio																																																																
C	2004	ALL	Body	Navigation Radio																																																																
C	2004	ALL	Body	Rear Aux. Climate Module																																																																
C	2004	ALL	Body	Rear HVAC																																																																
C	2004	ALL	Body	Rear Seat Audio																																																																
C	2004	ALL	Body	Rear Seat Entertainment																																																																
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																																
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																																
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																																
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																																
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																																
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																																
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																																
C	2005	ALL	Chassis	ESC																																																																
C	2005	ALL	Chassis	Rear Wheel Steering																																																																
C	2005	ALL	Chassis	Tire Pressure Monitor																																																																
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																																
C	2005	ALL	Chassis	VSES																																																																
C	2005	ALL	Body	Amplifier (Bose)																																																																
C	2005	ALL	Body	Body Control Module																																																																
C	2005	ALL	Body	CD Changer																																																																
C	2005	ALL	Body	Chime																																																																
C	2005	ALL	Body	Disc Player and Video Display																																																																
C	2005	ALL	Body	Driver Door Module																																																																
C	2005	ALL	Body	Driver Seat Module																																																																
C	2005	ALL	Body	Generator Battery Control Module																																																																
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																												
C	2005	ALL	Body	Instrument Panel Cluster																																																												
C	2005	ALL	Body	Passenger Door Module																																																												
C	2005	ALL	Body	Passenger Presence System																																																												
C	2005	ALL	Body	Base Radio																																																												
C	2005	ALL	Body	Uplevel Radio																																																												
C	2005	ALL	Body	Navigation Radio																																																												
C	2005	ALL	Body	Rear Aux. Climate Module																																																												
C	2005	ALL	Body	Rear HVAC																																																												
C	2005	ALL	Body	Rear Seat Audio																																																												
C	2005	ALL	Body	Remote Function Actuation																																																												
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																												
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																												
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																												
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2006	ALL	Chassis	ESC																																																											
C	2006	ALL	Chassis	Tire Pressure Monitor																																																											
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2006	ALL	Chassis	VSES																																																											
C	2006	ALL	Body	Amplifier (Bose)																																																												
C	2006	ALL	Body	Body Control Module																																																												
C	2006	ALL	Body	CD Changer																																																												
C	2006	ALL	Body	Chime																																																												
C	2006	ALL	Body	Disc Player and Video Display																																																												
C	2006	ALL	Body	Driver Door Module																																																												
C	2006	ALL	Body	Driver Seat Module																																																												
C	2006	ALL	Body	Generator Battery Control Module																																																												
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																												
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
C	2006	ALL	Body	Instrument Panel Cluster																																																												
C	2006	ALL	Body	Passenger Door Module																																																												
C	2006	ALL	Body	Passenger Presence System																																																												
C	2006	ALL	Body	Base Radio																																																												
C	2006	ALL	Body	Uplevel Radio																																																												
C	2006	ALL	Body	Navigation Radio																																																												
C	2006	ALL	Body	Rear Aux. Climate Module																																																												
C	2006	ALL	Body	Rear HVAC																																																												
C	2006	ALL	Body	Rear Seat Audio																																																												
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	ALL	Chassis	Electronic Brake Control Module																																																												
C	2007	ALL	Chassis	Electronic Suspension Control																																																												
C	2007	ALL	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2007	ALL	Body	Assist Step Controller																																																										
C	2007	ALL	Body	Body Control Module																																																										
C	2007	ALL	Body	Body Control Module (aux.)																																																										
C	2007	ALL	Body	Digital Radio Receiver																																																										
C	2007	ALL	Body	Driver Door Switch																																																										
C	2007	ALL	Body	HVAC Control Module																																																										
C	2007	ALL	Body	Inside Rear View Mirror Module																																																										
C	2007	ALL	Body	Instrument Panel Cluster																																																										
C	2007	ALL	Body	Lift Gate Module																																																										
C	2007	ALL	Body	Memory Seat Module																																																										
C	2007	ALL	Body	Park Assist Module																																																										
C	2007	ALL	Body	Passenger Door Switch																																																										
C	2007	ALL	Body	Passenger Presence System																																																										
C	2007	ALL	Body	Radio																																																										
C	2007	ALL	Body	Rear Heated Seat Module																																																										
C	2007	ALL	Body	Rear HVAC/RSA																																																										
C	2007	ALL	Body	Rollover Sensor																																																										
C	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2007	ALL	Body	Theft Deterrent Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	ALL	Chassis	Electronic Brake Control Module																																																										
C	2008	ALL	Chassis	Electronic Suspension Control																																																										
C	2008	ALL	Chassis	Trailer Brake Control Module																																																										
C	2008	ALL	Body	Amplifier (Bose)																																																										
C	2008	ALL	Body	Assist Step Controller																																																										
C	2008	ALL	Body	Body Control Module																																																										
C	2008	ALL	Body	Body Control Module (aux.)																																																										
C	2008	ALL	Body	Digital Radio Receiver																																																										
C	2008	ALL	Body	Driver Door Switch																																																										
C	2008	ALL	Body	HVAC Control Module																																																										
C	2008	ALL	Body	Inside Rear View Mirror Module																																																										
C	2008	ALL	Body	Instrument Panel Cluster																																																										
C	2008	ALL	Body	Lift Gate Module																																																										
C	2008	ALL	Body	Memory Seat Module																																																										
C	2008	ALL	Body	Park Assist Module																																																										
C	2008	ALL	Body	Passenger Door Switch																																																										
C	2008	ALL	Body	Passenger Presence System																																																										
C	2008	ALL	Body	Radio																																																										
C	2008	ALL	Body	Rear Heated Seat Module																																																										
C	2008	ALL	Body	Rear HVAC/RSA																																																										
C	2008	ALL	Body	Rollover Sensor																																																										
C	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2008	ALL	Body	Theft Deterrent Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	ALL	Chassis	Electronic Brake Control Module																																																										
C	2009	ALL	Chassis	Electronic Suspension Control																																																										
C	2009	ALL	Chassis	Trailer Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2009	ALL	Body	Amplifier (Bose)																																																															
C	2009	ALL	Body	Assist Step Controller																																																															
C	2009	ALL	Body	Body Control Module																																																															
C	2009	ALL	Body	Body Control Module (aux.)																																																															
C	2009	ALL	Body	Digital Radio Receiver																																																															
C	2009	ALL	Body	Driver Door Switch																																																															
C	2009	ALL	Body	HVAC Control Module																																																															
C	2009	ALL	Body	Inside Rear View Mirror Module																																																															
C	2009	ALL	Body	Instrument Panel Cluster																																																															
C	2009	ALL	Body	Left Side Object Detection Module																																																															
C	2009	ALL	Body	Lift Gate Module																																																															
C	2009	ALL	Body	Memory Seat Module																																																															
C	2009	ALL	Body	Park Assist Module																																																															
C	2009	ALL	Body	Passenger Door Switch																																																															
C	2009	ALL	Body	Passenger Presence System																																																															
C	2009	ALL	Body	Radio																																																															
C	2009	ALL	Body	Rear Heated Seat Module																																																															
C	2009	ALL	Body	Rear HVAC/RSA																																																															
C	2009	ALL	Body	Right Side Object Detection Module																																																															
C	2009	ALL	Body	Rollover Sensor																																																															
C	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
C	2009	ALL	Body	Theft Deterrent Module																																																															
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																															
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																															
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																															
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
C	2010	ALL	Chassis	Electronic Brake Control Module																																																															
C	2010	ALL	Chassis	Electronic Suspension Control																																																															
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																															
C	2010	ALL	Body	Amplifier (Bose)																																																															
C	2010	ALL	Body	Assist Step Controller																																																															
C	2010	ALL	Body	Body Control Module																																																															
C	2010	ALL	Body	Body Control Module (aux.)																																																															
C	2010	ALL	Body	Digital Radio Receiver																																																															
C	2010	ALL	Body	Driver Door Switch																																																															
C	2010	ALL	Body	HVAC Control Module																																																															
C	2010	ALL	Body	Inside Rear View Mirror Module																																																															
C	2010	ALL	Body	Instrument Panel Cluster																																																															
C	2010	ALL	Body	Left Side Object Detection Module																																																															
C	2010	ALL	Body	Lift Gate Module																																																															
C	2010	ALL	Body	Memory Seat Module																																																															
C	2010	ALL	Body	Park Assist Module																																																															
C	2010	ALL	Body	Passenger Door Switch																																																															
C	2010	ALL	Body	Passenger Presence System																																																															
C	2010	ALL	Body	Radio																																																															
C	2010	ALL	Body	Rear Heated Seat Module																																																															
C	2010	ALL	Body	Rear HVAC/RSA																																																															
C	2010	ALL	Body	Right Side Object Detection Module																																																															
C	2010	ALL	Body	Supplemental Inflatable Restraint																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2010	ALL	Body	Theft Deterrent Module																																																														
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																															
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																															
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																															
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																															
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																																															
E	2004	ALL	Chassis	Electronic Suspension Control																																																															
E	2004	ALL	Chassis	Tire Pressure Monitor																																																															
E	2004	ALL	Chassis	VES																																																															
E	2004	ALL	Body	Amplifier (Bose)																																																															
E	2004	ALL	Body	Amplifier (Delco)																																																															
E	2004	ALL	Body	Climate Control Panel																																																															
E	2004	ALL	Body	Dash Integration Module																																																															
E	2004	ALL	Body	Disc Player and Video Display																																																															
E	2004	ALL	Body	Driver Door Switch																																																															
E	2004	ALL	Body	Driver Door Module																																																															
E	2004	ALL	Body	Passenger Door Module																																																															
E	2004	ALL	Body	Left Rear Door Module																																																															
E	2004	ALL	Body	Right Rear Door Module																																																															
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																																															
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																																															
E	2004	ALL	Body	Instrument Panel Cluster																																																															
E	2004	ALL	Body	Memory Seat Module																																																															
E	2004	ALL	Body	OnStar																																																															
E	2004	ALL	Body	Personalization																																																															
E	2004	ALL	Body	Base Radio																																																															
E	2004	ALL	Body	Navigation Radio																																																															
E	2004	ALL	Body	Rear Integration Module																																																															
E	2004	ALL	Body	Rear Seat Module																																																															
E	2004	ALL	Body	Remote Function Actuation																																																															
E	2004	ALL	Body	Supplemental Inflatable Restraint																																																															
E	2004	ALL	Body	TV Antenna Module																																																															
E	2004	ALL	Body	Vehicle Theft Deterrent																																																															
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																															
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																															
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																															
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																															
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																																															
E	2005	ALL	Chassis	Electronic Suspension Control																																																															
E	2005	ALL	Chassis	Tire Pressure Monitor																																																															
E	2005	ALL	Chassis	VES																																																															
E	2005	ALL	Body	Amplifier (Bose)																																																															
E	2005	ALL	Body	Amplifier (Delco)																																																															
E	2005	ALL	Body	Climate Control Panel																																																															
E	2005	ALL	Body	Dash Integration Module																																																															
E	2005	ALL	Body	Disc Player and Video Display																																																															
E	2005	ALL	Body	Driver Door Switch																																																															
E	2005	ALL	Body	Driver Door Module																																																															
E	2005	ALL	Body	Passenger Door Module																																																															
E	2005	ALL	Body	Left Rear Door Module																																																															
E	2005	ALL	Body	Right Rear Door Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																																											
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																																												
E	2005	ALL	Body	Instrument Panel Cluster																																																												
E	2005	ALL	Body	Memory Seat Module																																																												
E	2005	ALL	Body	Personalization																																																												
E	2005	ALL	Body	Base Radio																																																												
E	2005	ALL	Body	Navigation Radio																																																												
E	2005	ALL	Body	Rear Integration Module																																																												
E	2005	ALL	Body	Rear Seat Module																																																												
E	2005	ALL	Body	Remote Function Actuation																																																												
E	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2005	ALL	Body	TV Antenna Module																																																												
E	2005	ALL	Body	Vehicle Comm. Interface Module																																																												
E	2005	ALL	Body	Vehicle Theft Deterrent																																																												
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																																												
E	2006	ALL	Chassis	Electronic Suspension Control																																																												
E	2006	ALL	Chassis	Tire Pressure Monitor																																																												
E	2006	ALL	Chassis	VES																																																												
E	2006	ALL	Body	Amplifier (Bose)																																																												
E	2006	ALL	Body	Amplifier (Delco)																																																												
E	2006	ALL	Body	Climate Control Panel																																																												
E	2006	ALL	Body	Dash Integration Module																																																												
E	2006	ALL	Body	Disc Player and Video Display																																																												
E	2006	ALL	Body	Driver Door Switch																																																												
E	2006	ALL	Body	Driver Door Module																																																												
E	2006	ALL	Body	Passenger Door Module																																																												
E	2006	ALL	Body	Left Rear Door Module																																																												
E	2006	ALL	Body	Right Rear Door Module																																																												
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																																												
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																																												
E	2006	ALL	Body	Instrument Panel Cluster																																																												
E	2006	ALL	Body	Lift Gate Module																																																												
E	2006	ALL	Body	Memory Seat Module																																																												
E	2006	ALL	Body	Personalization																																																												
E	2006	ALL	Body	Base Radio																																																												
E	2006	ALL	Body	Navigation Radio																																																												
E	2006	ALL	Body	Rear Integration Module																																																												
E	2006	ALL	Body	Rear Seat Module																																																												
E	2006	ALL	Body	Remote Function Actuation																																																												
E	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
E	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
E	2006	ALL	Body	Vehicle Theft Deterrent																																																												
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																												
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																												
E	2007	ALL	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
E	2007	ALL	Chassis	Electronic Suspension Control																																																												
E	2007	ALL	Body	Amplifier (Bose)																																																													
E	2007	ALL	Body	Body Control Module																																																													
E	2007	ALL	Body	Body Control Module (aux.)																																																													
E	2007	ALL	Body	Digital Radio Receiver																																																													
E	2007	ALL	Body	Driver Door Switch																																																													
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																																													
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																																													
E	2007	ALL	Body	HVAC Control Module																																																													
E	2007	ALL	Body	Instrument Panel Cluster																																																													
E	2007	ALL	Body	Lift Gate Module																																																													
E	2007	ALL	Body	Memory Seat Module																																																													
E	2007	ALL	Body	Park Assist Module																																																													
E	2007	ALL	Body	Passenger Door Switch																																																													
E	2007	ALL	Body	Passenger Presence System																																																													
E	2007	ALL	Body	Radio																																																													
E	2007	ALL	Body	Rear HVAC/RSA																																																													
E	2007	ALL	Body	Rear Seat Module																																																													
E	2007	ALL	Body	Remote Control Door Lock Receiver																																																													
E	2007	ALL	Body	Rollover Sensor																																																													
E	2007	ALL	Body	Supplemental Inflatable Restraint																																																													
E	2007	ALL	Body	Theft Deterrent Module																																																													
E	2007	ALL	Body	TV Antenna Module																																																													
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																													
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																													
E	2008	ALL	Chassis	Electronic Brake Control Module																																																													
E	2008	ALL	Chassis	Electronic Suspension Control																																																													
E	2008	ALL	Body	Amplifier (Bose)																																																													
E	2008	ALL	Body	Body Control Module																																																													
E	2008	ALL	Body	Body Control Module (aux.)																																																													
E	2008	ALL	Body	Digital Radio Receiver																																																													
E	2008	ALL	Body	Driver Door Switch																																																													
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																																													
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																																													
E	2008	ALL	Body	HVAC Control Module																																																													
E	2008	ALL	Body	Instrument Panel Cluster																																																													
E	2008	ALL	Body	Lift Gate Module																																																													
E	2008	ALL	Body	Memory Seat Module																																																													
E	2008	ALL	Body	Park Assist Module																																																													
E	2008	ALL	Body	Passenger Door Switch																																																													
E	2008	ALL	Body	Passenger Presence System																																																													
E	2008	ALL	Body	Radio																																																													
E	2008	ALL	Body	Rear HVAC/RSA																																																													
E	2008	ALL	Body	Rear Seat Module																																																													
E	2008	ALL	Body	Remote Control Door Lock Receiver																																																													
E	2008	ALL	Body	Rollover Sensor																																																													
E	2008	ALL	Body	Supplemental Inflatable Restraint																																																													
E	2008	ALL	Body	Theft Deterrent Module																																																													
E	2008	ALL	Body	TV Antenna Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																																													
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																																													
E	2009	ALL	Chassis	Electronic Brake Control Module																																																													
E	2009	ALL	Chassis	Electronic Suspension Control																																																													
E	2009	ALL	Body	Amplifier (Bose)																																																													
E	2009	ALL	Body	Body Control Module																																																													
E	2009	ALL	Body	Body Control Module (aux.)																																																													
E	2009	ALL	Body	Digital Radio Receiver																																																													
E	2009	ALL	Body	Driver Door Switch																																																													
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																																													
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																																													
E	2009	ALL	Body	HVAC Control Module																																																													
E	2009	ALL	Body	Instrument Panel Cluster																																																													
E	2009	ALL	Body	Lift Gate Module																																																													
E	2009	ALL	Body	Memory Seat Module																																																													
E	2009	ALL	Body	Park Assist Module																																																													
E	2009	ALL	Body	Passenger Door Switch																																																													
E	2009	ALL	Body	Passenger Presence System																																																													
E	2009	ALL	Body	Radio																																																												
E	2009	ALL	Body	Rear HVAC/RSA																																																													
E	2009	ALL	Body	Rear Seat Module																																																													
E	2009	ALL	Body	Remote Control Door Lock Receiver																																																													
E	2009	ALL	Body	Rollover Sensor																																																													
E	2009	ALL	Body	Supplemental Inflatable Restraint																																																													
E	2009	ALL	Body	Theft Deterrent Module																																																													
E	2009	ALL	Body	TV Antenna Module																																																													
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																													
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																													
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																													
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																													
K	2004	ALL	Chassis	ESC																																																													
K	2004	ALL	Chassis	Rear Wheel Steering																																																													
K	2004	ALL	Chassis	Tire Pressure Monitor																																																													
K	2004	ALL	Chassis	VSES																																																													
K	2004	ALL	Body	Amplifier (Bose)																																																													
K	2004	ALL	Body	Body Control Module																																																													
K	2004	ALL	Body	CD Changer																																																													
K	2004	ALL	Body	Chime																																																													
K	2004	ALL	Body	Driver Door Module																																																													
K	2004	ALL	Body	Driver Seat Module																																																													
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																													
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																													
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																													
K	2004	ALL	Body	Instrument Panel Cluster																																																													
K	2004	ALL	Body	OnStar																																																													
K	2004	ALL	Body	Passenger Door Module																																																													
K	2004	ALL	Body	Passenger Presence System																																																													
K	2004	ALL	Body	Base Radio																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2004	ALL	Body	Uplevel Radio																																																											
K	2004	ALL	Body	Navigation Radio																																																											
K	2004	ALL	Body	Rear Aux. Climate Module																																																											
K	2004	ALL	Body	Rear HVAC																																																											
K	2004	ALL	Body	Rear Seat Audio																																																											
K	2004	ALL	Body	Rear Seat Entertainment																																																											
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																											
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																											
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2005	ALL	Chassis	ESC																																																											
K	2005	ALL	Chassis	Rear Wheel Steering																																																												
K	2005	ALL	Chassis	Tire Pressure Monitor																																																												
K	2005	ALL	Chassis	VSES																																																											
K	2005	ALL	Body	Amplifier (Bose)																																																											
K	2005	ALL	Body	Body Control Module																																																											
K	2005	ALL	Body	CD Changer																																																											
K	2005	ALL	Body	Chime																																																											
K	2005	ALL	Body	Disc Player and Video Display																																																											
K	2005	ALL	Body	Driver Door Module																																																											
K	2005	ALL	Body	Driver Seat Module																																																											
K	2005	ALL	Body	Generator Battery Control Module																																																											
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																											
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2005	ALL	Body	Instrument Panel Cluster																																																											
K	2005	ALL	Body	Passenger Door Module																																																											
K	2005	ALL	Body	Passenger Presence System																																																											
K	2005	ALL	Body	Base Radio																																																											
K	2005	ALL	Body	Uplevel Radio																																																											
K	2005	ALL	Body	Navigation Radio																																																											
K	2005	ALL	Body	Rear Aux. Climate Module																																																											
K	2005	ALL	Body	Rear HVAC																																																											
K	2005	ALL	Body	Rear Seat Audio																																																											
K	2005	ALL	Body	Remote Function Actuation																																																											
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																											
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																																											
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																																											
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																											
K	2006	ALL	Chassis	ESC																																																											
K	2006	ALL	Chassis	Tire Pressure Monitor																																																											
K	2006	ALL	Chassis	VSES																																																											
K	2006	ALL	Body	Amplifier (Bose)																																																											
K	2006	ALL	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2006	ALL	Body	CD Changer																																																												
K	2006	ALL	Body	Chime																																																												
K	2006	ALL	Body	Disc Player and Video Display																																																													
K	2006	ALL	Body	Driver Door Module																																																												
K	2006	ALL	Body	Driver Seat Module																																																												
K	2006	ALL	Body	Generator Battery Control Module																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2006	ALL	Body	Instrument Panel Cluster																																																												
K	2006	ALL	Body	Passenger Door Module																																																												
K	2006	ALL	Body	Passenger Presence System																																																												
K	2006	ALL	Body	Base Radio																																																												
K	2006	ALL	Body	Uplevel Radio																																																												
K	2006	ALL	Body	Navigation Radio																																																												
K	2006	ALL	Body	Rear Aux. Climate Module																																																												
K	2006	ALL	Body	Rear HVAC																																																												
K	2006	ALL	Body	Rear Seat Audio																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2007	ALL	Chassis	Electronic Brake Control Module																																																												
K	2007	ALL	Chassis	Electronic Suspension Control																																																												
K	2007	ALL	Body	Amplifier (Bose)																																																												
K	2007	ALL	Body	Assist Step Controller																																																												
K	2007	ALL	Body	Body Control Module																																																												
K	2007	ALL	Body	Body Control Module (aux.)																																																												
K	2007	ALL	Body	Digital Radio Receiver																																																												
K	2007	ALL	Body	Driver Door Switch																																																												
K	2007	ALL	Body	HVAC Control Module																																																												
K	2007	ALL	Body	Inside Rear View Mirror Module																																																												
K	2007	ALL	Body	Instrument Panel Cluster																																																												
K	2007	ALL	Body	Lift Gate Module																																																												
K	2007	ALL	Body	Memory Seat Module																																																												
K	2007	ALL	Body	Park Assist Module																																																												
K	2007	ALL	Body	Passenger Door Switch																																																												
K	2007	ALL	Body	Passenger Presence System																																																												
K	2007	ALL	Body	Radio																																																												
K	2007	ALL	Body	Rear Heated Seat Module																																																												
K	2007	ALL	Body	Rear HVAC/RSA																																																												
K	2007	ALL	Body	Rollover Sensor																																																												
K	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2007	ALL	Body	Theft Deterrent Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2008	ALL	Chassis	Electronic Brake Control Module																																																												
K	2008	ALL	Chassis	Electronic Suspension Control																																																												
K	2008	ALL	Chassis	Trailer Brake Control Module																																																												
K	2008	ALL	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2008	ALL	Body	Assist Step Controller																																																										
K	2008	ALL	Body	Body Control Module																																																										
K	2008	ALL	Body	Body Control Module (aux.)																																																										
K	2008	ALL	Body	Digital Radio Receiver																																																										
K	2008	ALL	Body	Driver Door Switch																																																										
K	2008	ALL	Body	HVAC Control Module																																																										
K	2008	ALL	Body	Inside Rear View Mirror Module																																																										
K	2008	ALL	Body	Instrument Panel Cluster																																																										
K	2008	ALL	Body	Lift Gate Module																																																										
K	2008	ALL	Body	Memory Seat Module																																																										
K	2008	ALL	Body	Park Assist Module																																																										
K	2008	ALL	Body	Passenger Door Switch																																																										
K	2008	ALL	Body	Passenger Presence System																																																										
K	2008	ALL	Body	Radio																																																										
K	2008	ALL	Body	Rear Heated Seat Module																																																										
K	2008	ALL	Body	Rear HVAC/RSA																																																										
K	2008	ALL	Body	Rollover Sensor																																																										
K	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2008	ALL	Body	Theft Deterrent Module																																																										
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	ALL	Chassis	Electronic Brake Control Module																																																										
K	2009	ALL	Chassis	Electronic Suspension Control																																																										
K	2009	ALL	Chassis	Trailer Brake Control Module																																																										
K	2009	ALL	Body	Amplifier (Bose)																																																										
K	2009	ALL	Body	Assist Step Controller																																																										
K	2009	ALL	Body	Body Control Module																																																										
K	2009	ALL	Body	Body Control Module (aux.)																																																										
K	2009	ALL	Body	Digital Radio Receiver																																																										
K	2009	ALL	Body	Driver Door Switch																																																										
K	2009	ALL	Body	HVAC Control Module																																																										
K	2009	ALL	Body	Inside Rear View Mirror Module																																																										
K	2009	ALL	Body	Instrument Panel Cluster																																																										
K	2009	ALL	Body	Left Side Object Detection Module																																																										
K	2009	ALL	Body	Lift Gate Module																																																										
K	2009	ALL	Body	Memory Seat Module																																																										
K	2009	ALL	Body	Park Assist Module																																																										
K	2009	ALL	Body	Passenger Door Switch																																																										
K	2009	ALL	Body	Passenger Presence System																																																										
K	2009	ALL	Body	Radio																																																										
K	2009	ALL	Body	Rear Heated Seat Module																																																										
K	2009	ALL	Body	Rear HVAC/RSA																																																										
K	2009	ALL	Body	Right Side Object Detection Module																																																										
K	2009	ALL	Body	Rollover Sensor																																																										
K	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2009	ALL	Body	Theft Deterrent Module																																																										
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
K	2010	ALL	Chassis	Electronic Brake Control Module																																																														
K	2010	ALL	Chassis	Electronic Suspension Control																																																														
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																																														
K	2010	ALL	Body	Amplifier (Bose)																																																														
K	2010	ALL	Body	Assist Step Controller																																																														
K	2010	ALL	Body	Body Control Module																																																														
K	2010	ALL	Body	Body Control Module (aux.)																																																														
K	2010	ALL	Body	Digital Radio Receiver																																																														
K	2010	ALL	Body	Driver Door Switch																																																														
K	2010	ALL	Body	HVAC Control Module																																																														
K	2010	ALL	Body	Inside Rear View Mirror Module																																																														
K	2010	ALL	Body	Instrument Panel Cluster																																																														
K	2010	ALL	Body	Left Side Object Detection Module																																																														
K	2010	ALL	Body	Lift Gate Module																																																														
K	2010	ALL	Body	Memory Seat Module																																																														
K	2010	ALL	Body	Park Assist Module																																																														
K	2010	ALL	Body	Passenger Door Switch																																																														
K	2010	ALL	Body	Passenger Presence System																																																														
K	2010	ALL	Body	Radio																																																														
K	2010	ALL	Body	Rear Heated Seat Module																																																														
K	2010	ALL	Body	Rear HVAC/RSA																																																														
K	2010	ALL	Body	Right Side Object Detection Module																																																														
K	2010	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2010	ALL	Body	Theft Deterrent Module																																																														
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																																														
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																																														
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																																														
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																														
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																														
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																														
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																																														
N	2010	SRX	Chassis	Electronic Brake Control Module																																																														
N	2010	SRX	Chassis	Parking Brake Control Module																																																														
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																														
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																																														
N	2010	SRX	Chassis	Suspension Control Module																																																														
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																														
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																														
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
N	2010	SRX	Body	Passenger Presence Module																																																															
N	2010	SRX	Body	Instrument Cluster																																																															
N	2010	SRX	Body	Headlamp Control Module																																																															
N	2010	SRX	Body	Trailer Interface Control Module																																																															
N	2010	SRX	Body	Radio																																																															
N	2010	SRX	Body	Rear Audio Control Module																																																															
N	2010	SRX	Body	Digital Radio Receiver Control Module																																																															
N	2010	SRX	Body	Multimedia Player Interface Module																																																															
N	2010	SRX	Body	Mobile Telephone Control Module																																																															
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2010	SRX	Body	Liftgate Control Module																																																										
N	2010	SRX	Body	Seat Memory Control Module																																																										
N	2010	SRX	Body	Front Seat Heating Control Module																																																										
N	2010	SRX	Body	Rear Seat Heating Control Module																																																										
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2010	SRX	Body	Parking Assist Control Module																																																										
N	2010	SRX	Body	Steering Column Lock Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																																										
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2011	SRX	Chassis	Electronic Brake Control Module																																																										
N	2011	SRX	Chassis	Parking Brake Control Module																																																										
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2011	SRX	Chassis	Suspension Control Module																																																										
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2011	SRX	Body	Passenger Presence Module																																																										
N	2011	SRX	Body	Instrument Cluster																																																										
N	2011	SRX	Body	Headlamp Control Module																																																										
N	2011	SRX	Body	Trailer Interface Control Module																																																										
N	2011	SRX	Body	Radio																																																										
N	2011	SRX	Body	Rear Audio Control Module																																																										
N	2011	SRX	Body	Digital Radio Receiver Control Module																																																										
N	2011	SRX	Body	Multimedia Player Interface Module																																																										
N	2011	SRX	Body	Mobile Telephone Control Module																																																										
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																										
N	2011	SRX	Body	Liftgate Control Module																																																										
N	2011	SRX	Body	Seat Memory Control Module																																																										
N	2011	SRX	Body	Front Seat Heating Control Module																																																										
N	2011	SRX	Body	Rear Seat Heating Control Module																																																										
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2011	SRX	Body	Parking Assist Control Module																																																										
N	2011	SRX	Body	Steering Column Lock Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																																											
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2012	SRX	Chassis	Electronic Brake Control Module																																																												
N	2012	SRX	Chassis	Parking Brake Control Module																																																												
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2012	SRX	Chassis	Suspension Control Module																																																												
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2012	SRX	Body	Passenger Presence Module																																																												
N	2012	SRX	Body	Instrument Cluster																																																												
N	2012	SRX	Body	Headlamp Control Module																																																												
N	2012	SRX	Body	Trailer Interface Control Module																																																												
N	2012	SRX	Body	Radio																																																												
N	2012	SRX	Body	Rear Audio Control Module																																																												
N	2012	SRX	Body	Digital Radio Receiver Control Module																																																												
N	2012	SRX	Body	Multimedia Player Interface Module																																																												
N	2012	SRX	Body	Mobile Telephone Control Module																																																												
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																																												
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																																												
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																																												
N	2012	SRX	Body	Liftgate Control Module																																																												
N	2012	SRX	Body	Seat Memory Control Module																																																												
N	2012	SRX	Body	Front Seat Heating Control Module																																																												
N	2012	SRX	Body	Rear Seat Heating Control Module																																																												
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																																												
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																												
N	2012	SRX	Body	Parking Assist Control Module																																																												
N	2012	SRX	Body	Steering Column Lock Control Module																																																												
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2013	SRX	Chassis	Electronic Brake Control Module																																																												
N	2013	SRX	Chassis	Parking Brake Control Module																																																												
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2013	SRX	Chassis	Suspension Control Module																																																												
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2013	SRX	Body	Passenger Presence Module																																																												
N	2013	SRX	Body	Instrument Cluster																																																												
N	2013	SRX	Body	Radio/HVAC Control																																																												
N	2013	SRX	Body	Active Safety Control Module																																																												
N	2013	SRX	Body	Headlamp Control Module																																																												
N	2013	SRX	Body	Trailer Interface Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
N	2013	SRX	Body	Radio																																																										
N	2013	SRX	Body	Amplifier																																																										
N	2013	SRX	Body	Media Disc Player																																																										
N	2013	SRX	Body	Human Machine Interface Control Module																																																										
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																																										
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2013	SRX	Body	Liftgate Control Module																																																										
N	2013	SRX	Body	Seat Memory Control Module																																																										
N	2013	SRX	Body	Rear Seat Heating Control Module																																																										
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																																										
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																										
N	2013	SRX	Body	Right Side Object Detection Control Module																																																										
N	2013	SRX	Body	Left Side Object Detection Control Module																																																										
N	2013	SRX	Body	Parking Assist Control Module																																																										
N	2013	SRX	Body	Frontview Camera Module																																																										
N	2013	SRX	Body	Steering Column Lock Control Module																																																										
N	2013	SRX	Body	Long Range Radar Sensor Module																																																										
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																																										
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																																										
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																																										
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																																										
N	2014	SRX	Chassis	Electronic Brake Control Module																																																										
N	2014	SRX	Chassis	Parking Brake Control Module																																																										
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																										
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																																										
N	2014	SRX	Chassis	Suspension Control Module																																																										
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																										
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																										
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
N	2014	SRX	Body	Passenger Presence Module																																																										
N	2014	SRX	Body	Instrument Cluster																																																										
N	2014	SRX	Body	Radio/HVAC Control																																																										
N	2014	SRX	Body	Active Safety Control Module																																																										
N	2014	SRX	Body	Headlamp Control Module																																																										
N	2014	SRX	Body	Trailer Interface Control Module																																																										
N	2014	SRX	Body	Radio																																																										
N	2014	SRX	Body	Amplifier																																																										
N	2014	SRX	Body	Media Disc Player																																																										
N	2014	SRX	Body	Human Machine Interface Control Module																																																										
N	2014	SRX	Body	Navigation Control Module																																																										
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																										
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																																										
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																										
N	2014	SRX	Body	Liftgate Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
N	2014	SRX	Body	Seat Memory Control Module - Driver																																																											
N	2014	SRX	Body	Rear Seat Heating Control Module																																																												
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																																												
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																												
N	2014	SRX	Body	Right Side Object Detection Control Module																																																												
N	2014	SRX	Body	Left Side Object Detection Control Module																																																												
N	2014	SRX	Body	Parking Assist Control Module																																																												
N	2014	SRX	Body	Frontview Camera Module																																																												
N	2014	SRX	Body	Steering Column Lock Control Module																																																												
N	2014	SRX	Body	Long Range Radar Sensor Module																																																												
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																																												
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																																												
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																																												
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																																												
N	2015	SRX	Chassis	Electronic Brake Control Module																																																												
N	2015	SRX	Chassis	Parking Brake Control Module																																																												
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																												
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																																												
N	2015	SRX	Chassis	Suspension Control Module																																																												
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																												
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																												
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
N	2015	SRX	Body	Passenger Presence Module																																																												
N	2015	SRX	Body	Instrument Cluster																																																												
N	2015	SRX	Body	Radio/HVAC Control																																																												
N	2015	SRX	Body	Active Safety Control Module																																																												
N	2015	SRX	Body	Headlamp Control Module																																																												
N	2015	SRX	Body	Trailer Interface Control Module																																																												
N	2015	SRX	Body	Radio																																																												
N	2015	SRX	Body	Amplifier																																																												
N	2015	SRX	Body	Rear Audio Control Module																																																												
N	2015	SRX	Body	Media Disc Player																																																												
N	2015	SRX	Body	Human Machine Interface Control Module																																																												
N	2015	SRX	Body	Navigation Control Module																																																												
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																												
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																																												
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																												
N	2015	SRX	Body	Liftgate Control Module																																																												
N	2015	SRX	Body	Seat Memory Control Module - Driver																																																												
N	2015	SRX	Body	Rear Seat Heating Control Module																																																												
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																																												
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																												
N	2015	SRX	Body	Right Side Object Detection Control Module																																																												
N	2015	SRX	Body	Left Side Object Detection Control Module																																																												
N	2015	SRX	Body	Parking Assist Control Module																																																												
N	2015	SRX	Body	Frontview Camera Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
N	2015	SRX	Body	Steering Column Lock Control Module																																																												
N	2015	SRX	Body	Long Range Radar Sensor Module																																																													
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																																													
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																																													
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																																													
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																																													
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																																													
N	2016	SRX	Chassis	Electronic Brake Control Module																																																													
N	2016	SRX	Chassis	Parking Brake Control Module																																																													
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																																													
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																																													
N	2016	SRX	Chassis	Suspension Control Module																																																													
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																																													
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																																													
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
N	2016	SRX	Body	Passenger Presence Module																																																													
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																																													
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																																													
N	2016	SRX	Body	Radio/HVAC Control																																																													
N	2016	SRX	Body	Active Safety Control Module																																																													
N	2016	SRX	Body	Headlamp Control Module																																																													
N	2016	SRX	Body	Trailer Interface Control Module																																																													
N	2016	SRX	Body	Radio																																																													
N	2016	SRX	Body	Amplifier																																																													
N	2016	SRX	Body	Rear Audio Control Module																																																													
N	2016	SRX	Body	Media Disc Player																																																													
N	2016	SRX	Body	Human Machine Interface Control Module																																																													
N	2016	SRX	Body	Navigation Control Module																																																													
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																																													
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																																													
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																																													
N	2016	SRX	Body	Liftgate Control Module																																																													
N	2016	SRX	Body	Seat Memory Control Module - Driver																																																													
N	2016	SRX	Body	Rear Seat Heating Control Module																																																													
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																																													
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																																													
N	2016	SRX	Body	Right Side Object Detection Control Module																																																													
N	2016	SRX	Body	Left Side Object Detection Control Module																																																													
N	2016	SRX	Body	Parking Assist Control Module																																																													
N	2016	SRX	Body	Frontview Camera Module																																																													
N	2016	SRX	Body	Steering Column Lock Control Module																																																													
N	2016	SRX	Body	Long Range Radar Sensor Module																																																													
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																																													
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																																													
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																																													
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																													
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
3	2011	ALL	Chassis	Electronic Brake Control Module																																																													
3	2011	ALL	Chassis	Electronic Suspension Control																																																													
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																													
3	2011	ALL	Body	Amplifier (Bose)																																																													
3	2011	ALL	Body	Assist Step Controller																																																													
3	2011	ALL	Body	Body Control Module																																																													
3	2011	ALL	Body	Body Control Module (aux.)																																																													
3	2011	ALL	Body	Digital Radio Receiver																																																													
3	2011	ALL	Body	Driver Door Switch																																																													
3	2011	ALL	Body	HVAC Control Module																																																													
3	2011	ALL	Body	Inside Rear View Mirror Module																																																													
3	2011	ALL	Body	Instrument Panel Cluster																																																													
3	2011	ALL	Body	Left Side Object Detection Module																																																													
3	2011	ALL	Body	Lift Gate Module																																																													
3	2011	ALL	Body	Memory Seat Module																																																													
3	2011	ALL	Body	Park Assist Module																																																													
3	2011	ALL	Body	Passenger Door Switch																																																													
3	2011	ALL	Body	Passenger Presence System																																																													
3	2011	ALL	Body	Radio																																																													
3	2011	ALL	Body	Rear Heated Seat Module																																																													
3	2011	ALL	Body	Rear HVAC/RSA																																																													
3	2011	ALL	Body	Right Side Object Detection Module																																																													
3	2011	ALL	Body	Supplemental Inflatable Restraint																																																													
3	2011	ALL	Body	Theft Deterrent Module																																																													
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																													
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																													
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
3	2012	ALL	Chassis	Electronic Brake Control Module																																																													
3	2012	ALL	Chassis	Electronic Suspension Control																																																													
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																													
3	2012	ALL	Body	Amplifier (Bose)																																																													
3	2012	ALL	Body	Assist Step Controller																																																													
3	2012	ALL	Body	Body Control Module																																																													
3	2012	ALL	Body	Body Control Module (aux.)																																																													
3	2012	ALL	Body	Driver Door Switch																																																													
3	2012	ALL	Body	HVAC Control Module																																																													
3	2012	ALL	Body	Inside Rear View Mirror Module																																																													
3	2012	ALL	Body	Instrument Panel Cluster																																																													
3	2012	ALL	Body	Left Side Object Detection Module																																																													
3	2012	ALL	Body	Lift Gate Module																																																													
3	2012	ALL	Body	Memory Seat Module																																																													
3	2012	ALL	Body	Park Assist Module																																																													
3	2012	ALL	Body	Passenger Door Switch																																																													
3	2012	ALL	Body	Passenger Presence System																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
3	2012	ALL	Body	Radio																																																											
3	2012	ALL	Body	Rear Heated Seat Module																																																												
3	2012	ALL	Body	Rear HVAC/RSA																																																												
3	2012	ALL	Body	Right Side Object Detection Module																																																												
3	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
3	2012	ALL	Body	Theft Deterrent Module																																																												
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
3	2013	ALL	Chassis	Electronic Brake Control Module																																																												
3	2013	ALL	Chassis	Electronic Suspension Control																																																												
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																												
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																												
3	2013	ALL	Body	Amplifier (Bose)																																																												
3	2013	ALL	Body	Assist Step Controller																																																												
3	2013	ALL	Body	Body Control Module																																																												
3	2013	ALL	Body	Body Control Module (aux.)																																																												
3	2013	ALL	Body	Driver Door Switch																																																												
3	2013	ALL	Body	HVAC Control Module																																																												
3	2013	ALL	Body	Inside Rear View Mirror Module																																																												
3	2013	ALL	Body	Instrument Panel Cluster																																																												
3	2013	ALL	Body	Left Side Object Detection Module																																																												
3	2013	ALL	Body	Lift Gate Module																																																												
3	2013	ALL	Body	Memory Seat Module																																																												
3	2013	ALL	Body	Park Assist Module																																																												
3	2013	ALL	Body	Passenger Door Switch																																																												
3	2013	ALL	Body	Passenger Presence System																																																												
3	2013	ALL	Body	Radio																																																												
3	2013	ALL	Body	Rear Heated Seat Module																																																												
3	2013	ALL	Body	Rear HVAC/RSA																																																												
3	2013	ALL	Body	Right Side Object Detection Module																																																												
3	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
3	2013	ALL	Body	Theft Deterrent Module																																																												
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																												
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
3	2014	Escalade	Chassis	Electronic Brake Control Module																																																												
3	2014	Escalade	Chassis	Suspension Control Module																																																												
3	2014	Escalade	Body	Body Control Module																																																												
3	2014	Escalade	Body	Auxiliary Body Control Module																																																												
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
3	2014	Escalade	Body	Passenger Presence Module																																																												
3	2014	Escalade	Body	Instrument Cluster																																																												
3	2014	Escalade	Body	Radio																																																												
3	2014	Escalade	Body	Amplifier																																																												
3	2014	Escalade	Body	Rear Audio Control Module																																																												
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																																												
3	2014	Escalade	Body	Personal Audio Link Control Module																																																												
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																												
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
3	2014	Escalade	Body	HVAC Control Module																																																												
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																												
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																												
3	2014	Escalade	Body	Liftgate Control Module																																																												
3	2014	Escalade	Body	Seat Memory Control Module																																																												
3	2014	Escalade	Body	Rear Seat Heating Control Module																																																												
3	2014	Escalade	Body	Assist Step Control Module																																																												
3	2014	Escalade	Body	Right Side Object Detection Control Module																																																												
3	2014	Escalade	Body	Left Side Object Detection Control Module																																																												
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																																												
3	2014	Escalade	Body	Parking Assist Control Module																																																												
3	2014	Escalade	Body	Theft Deterrent Module																																																												
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																												
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																												
3	2014	Escalade ESV	Chassis	Suspension Control Module																																																												
3	2014	Escalade ESV	Body	Body Control Module																																																												
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																												
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
3	2014	Escalade ESV	Body	Passenger Presence Module																																																												
3	2014	Escalade ESV	Body	Instrument Cluster																																																												
3	2014	Escalade ESV	Body	Radio																																																												
3	2014	Escalade ESV	Body	Amplifier																																																												
3	2014	Escalade ESV	Body	Rear Audio Control Module																																																												
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																												
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																												
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																												
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																												
3	2014	Escalade ESV	Body	HVAC Control Module																																																												
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																												
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																												
3	2014	Escalade ESV	Body	Liftgate Control Module																																																												
3	2014	Escalade ESV	Body	Seat Memory Control Module																																																												
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																												
3	2014	Escalade ESV	Body	Assist Step Control Module																																																												
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																												
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																												
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																												
3	2014	Escalade ESV	Body	Parking Assist Control Module																																																												
3	2014	Escalade ESV	Body	Theft Deterrent Module																																																												
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																											
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																											
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																																
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																																
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																																
3	2015	Escalade	Chassis	Electronic Brake Control Module																																																																
3	2015	Escalade	Chassis	Parking Brake Control Module																																																																
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																																
3	2015	Escalade	Chassis	Power Steering Control Module																																																																
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																																
3	2015	Escalade	Chassis	Suspension Control Module																																																																
3	2015	Escalade	Body	Body Control Module																																																																
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
3	2015	Escalade	Body	Passenger Presence Module																																																																
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																																
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																																
3	2015	Escalade	Body	Instrument Cluster																																																																
3	2015	Escalade	Body	Radio/HVAC Control																																																																
3	2015	Escalade	Body	Active Safety Control Module																																																																
3	2015	Escalade	Body	Video Processing Control Module																																																																
3	2015	Escalade	Body	Radio																																																																
3	2015	Escalade	Body	Amplifier																																																																
3	2015	Escalade	Body	Media Disc Player																																																																
3	2015	Escalade	Body	Human Machine Interface Control Module																																																																
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																																
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																																
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																																
3	2015	Escalade	Body	HVAC Control Module																																																																
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																																
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																																
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																																
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																																																
3	2015	Escalade	Body	Keyless Entry Control Module																																																																
3	2015	Escalade	Body	Assist Step Control Module																																																																
3	2015	Escalade	Body	Left Side Object Detection Control Module																																																																
3	2015	Escalade	Body	Parking Assist Control Module																																																																
3	2015	Escalade	Body	Frontview Camera Module																																																																
3	2015	Escalade	Body	Steering Column Lock Control Module																																																																
3	2015	Escalade	Body	Battery Energy Control Module																																																																
3	2015	Escalade	Body	Long Range Radar Sensor Module																																																																
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																																
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																																
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																																
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																																
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																																
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																																
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																																
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																																
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																																
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																																
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																																
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																																
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																											
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																											
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																											
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																																											
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																											
3	2015	Escalade ESV	Chassis	Suspension Control Module																																																											
3	2015	Escalade ESV	Body	Body Control Module																																																											
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
3	2015	Escalade ESV	Body	Passenger Presence Module																																																											
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																											
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																											
3	2015	Escalade ESV	Body	Instrument Cluster																																																											
3	2015	Escalade ESV	Body	Radio/HVAC Control																																																											
3	2015	Escalade ESV	Body	Active Safety Control Module																																																											
3	2015	Escalade ESV	Body	Video Processing Control Module																																																											
3	2015	Escalade ESV	Body	Radio																																																											
3	2015	Escalade ESV	Body	Amplifier																																																											
3	2015	Escalade ESV	Body	Media Disc Player																																																											
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																											
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																											
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																											
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																											
3	2015	Escalade ESV	Body	HVAC Control Module																																																											
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																											
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																																											
3	2015	Escalade ESV	Body	Assist Step Control Module																																																											
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																											
3	2015	Escalade ESV	Body	Parking Assist Control Module																																																											
3	2015	Escalade ESV	Body	Frontview Camera Module																																																											
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																											
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																											
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																											
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																											
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																											
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																											
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
3	2016	Escalade	Chassis	Electronic Brake Control Module																																																											
3	2016	Escalade	Chassis	Parking Brake Control Module																																																											
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																											
3	2016	Escalade	Chassis	Power Steering Control Module																																																											
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																											
3	2016	Escalade	Chassis	Suspension Control Module																																																											
3	2016	Escalade	Body	Body Control Module																																																											
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
3	2016	Escalade	Body	Passenger Presence Module																																																												
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																												
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																												
3	2016	Escalade	Body	Instrument Cluster																																																												
3	2016	Escalade	Body	Radio/HVAC Control																																																												
3	2016	Escalade	Body	Active Safety Control Module																																																												
3	2016	Escalade	Body	Video Processing Control Module																																																												
3	2016	Escalade	Body	Radio																																																												
3	2016	Escalade	Body	Amplifier																																																												
3	2016	Escalade	Body	Media Disc Player																																																												
3	2016	Escalade	Body	Human Machine Interface Control Module																																																												
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																																												
3	2016	Escalade	Body	HVAC Control Module																																																												
3	2016	Escalade	Body	Liftgate Control Module																																																												
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																												
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																																												
3	2016	Escalade	Body	Keyless Entry Control Module																																																												
3	2016	Escalade	Body	Assist Step Control Module																																																												
3	2016	Escalade	Body	Left Side Object Detection Control Module																																																												
3	2016	Escalade	Body	Parking Assist Control Module																																																												
3	2016	Escalade	Body	Frontview Camera Module																																																												
3	2016	Escalade	Body	Steering Column Lock Control Module																																																												
3	2016	Escalade	Body	Long Range Radar Sensor Module																																																												
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																												
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																												
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																												
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																												
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																												
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																												
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																												
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																																												
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																												
3	2016	Escalade ESV	Chassis	Suspension Control Module																																																												
3	2016	Escalade ESV	Body	Body Control Module																																																												
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
3	2016	Escalade ESV	Body	Passenger Presence Module																																																												
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																												
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																												
3	2016	Escalade ESV	Body	Instrument Cluster																																																												
3	2016	Escalade ESV	Body	Radio Control																																																												
3	2016	Escalade ESV	Body	HVAC Control																																																												
3	2016	Escalade ESV	Body	Active Safety Control Module																																																												
3	2016	Escalade ESV	Body	Video Processing Control Module																																																												
3	2016	Escalade ESV	Body	Radio																																																												
3	2016	Escalade ESV	Body	Amplifier																																																												
3	2016	Escalade ESV	Body	Media Disc Player																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																												
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																												
3	2016	Escalade ESV	Body	HVAC Control Module																																																												
3	2016	Escalade ESV	Body	Liftgate Control Module																																																												
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																												
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																												
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																																												
3	2016	Escalade ESV	Body	Assist Step Control Module																																																												
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																												
3	2016	Escalade ESV	Body	Parking Assist Control Module																																																												
3	2016	Escalade ESV	Body	Frontview Camera Module																																																												
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																												
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																												
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																												
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																												
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																												
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																												
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
4	2011	ALL	Chassis	Electronic Brake Control Module																																																												
4	2011	ALL	Chassis	Electronic Suspension Control																																																												
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																																												
4	2011	ALL	Body	Amplifier (Bose)																																																												
4	2011	ALL	Body	Assist Step Controller																																																												
4	2011	ALL	Body	Body Control Module																																																												
4	2011	ALL	Body	Body Control Module (aux.)																																																												
4	2011	ALL	Body	Driver Door Switch																																																												
4	2011	ALL	Body	HVAC Control Module																																																												
4	2011	ALL	Body	Inside Rear View Mirror Module																																																												
4	2011	ALL	Body	Instrument Panel Cluster																																																												
4	2011	ALL	Body	Left Side Object Detection Module																																																												
4	2011	ALL	Body	Lift Gate Module																																																												
4	2011	ALL	Body	Memory Seat Module																																																												
4	2011	ALL	Body	Park Assist Module																																																												
4	2011	ALL	Body	Passenger Door Switch																																																												
4	2011	ALL	Body	Passenger Presence System																																																												
4	2011	ALL	Body	Radio																																																											
4	2011	ALL	Body	Rear Heated Seat Module																																																												
4	2011	ALL	Body	Rear HVAC/RSA																																																												
4	2011	ALL	Body	Right Side Object Detection Module																																																												
4	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
4	2011	ALL	Body	Theft Deterrent Module																																																												
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
4	2012	ALL	Chassis	Electronic Brake Control Module																																																											
4	2012	ALL	Chassis	Electronic Suspension Control																																																											
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2012	ALL	Body	Amplifier (Bose)																																																											
4	2012	ALL	Body	Assist Step Controller																																																											
4	2012	ALL	Body	Body Control Module																																																											
4	2012	ALL	Body	Body Control Module (aux.)																																																											
4	2012	ALL	Body	Driver Door Switch																																																											
4	2012	ALL	Body	HVAC Control Module																																																											
4	2012	ALL	Body	Inside Rear View Mirror Module																																																											
4	2012	ALL	Body	Instrument Panel Cluster																																																											
4	2012	ALL	Body	Left Side Object Detection Module																																																											
4	2012	ALL	Body	Lift Gate Module																																																											
4	2012	ALL	Body	Memory Seat Module																																																											
4	2012	ALL	Body	Park Assist Module																																																											
4	2012	ALL	Body	Passenger Door Switch																																																											
4	2012	ALL	Body	Passenger Presence System																																																											
4	2012	ALL	Body	Radio																																																											
4	2012	ALL	Body	Rear Heated Seat Module																																																											
4	2012	ALL	Body	Rear HVAC/RSA																																																											
4	2012	ALL	Body	Right Side Object Detection Module																																																											
4	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
4	2012	ALL	Body	Theft Deterrent Module																																																											
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
4	2013	ALL	Chassis	Electronic Brake Control Module																																																											
4	2013	ALL	Chassis	Electronic Suspension Control																																																											
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																																											
4	2013	ALL	Body	Amplifier (Bose)																																																											
4	2013	ALL	Body	Assist Step Controller																																																											
4	2013	ALL	Body	Body Control Module																																																											
4	2013	ALL	Body	Body Control Module (aux.)																																																											
4	2013	ALL	Body	Driver Door Switch																																																											
4	2013	ALL	Body	HVAC Control Module																																																											
4	2013	ALL	Body	Inside Rear View Mirror Module																																																											
4	2013	ALL	Body	Instrument Panel Cluster																																																											
4	2013	ALL	Body	Left Side Object Detection Module																																																											
4	2013	ALL	Body	Lift Gate Module																																																											
4	2013	ALL	Body	Memory Seat Module																																																											
4	2013	ALL	Body	Park Assist Module																																																											
4	2013	ALL	Body	Passenger Door Switch																																																											
4	2013	ALL	Body	Passenger Presence System																																																											
4	2013	ALL	Body	Radio																																																											
4	2013	ALL	Body	Rear Heated Seat Module																																																											
4	2013	ALL	Body	Rear HVAC/RSA																																																											
4	2013	ALL	Body	Right Side Object Detection Module																																																											
4	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
4	2013	ALL	Body	Theft Deterrent Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																																															
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																																															
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																																															
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																															
4	2014	Escalade	Chassis	Electronic Brake Control Module																																																															
4	2014	Escalade	Chassis	Suspension Control Module																																																															
4	2014	Escalade	Body	Body Control Module																																																															
4	2014	Escalade	Body	Auxiliary Body Control Module																																																															
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
4	2014	Escalade	Body	Passenger Presence Module																																																															
4	2014	Escalade	Body	Instrument Cluster																																																															
4	2014	Escalade	Body	Radio																																																															
4	2014	Escalade	Body	Amplifier																																																															
4	2014	Escalade	Body	Rear Audio Control Module																																																															
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																																															
4	2014	Escalade	Body	Personal Audio Link Control Module																																																															
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																																															
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																															
4	2014	Escalade	Body	HVAC Control Module																																																															
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																																																															
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																																															
4	2014	Escalade	Body	Liftgate Control Module																																																															
4	2014	Escalade	Body	Seat Memory Control Module																																																															
4	2014	Escalade	Body	Rear Seat Heating Control Module																																																															
4	2014	Escalade	Body	Assist Step Control Module																																																															
4	2014	Escalade	Body	Right Side Object Detection Control Module																																																															
4	2014	Escalade	Body	Left Side Object Detection Control Module																																																															
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																																															
4	2014	Escalade	Body	Parking Assist Control Module																																																															
4	2014	Escalade	Body	Theft Deterrent Module																																																															
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																																															
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																																															
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																																															
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																															
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																																															
4	2014	Escalade ESV	Chassis	Suspension Control Module																																																															
4	2014	Escalade ESV	Body	Body Control Module																																																															
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																																															
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
4	2014	Escalade ESV	Body	Passenger Presence Module																																																															
4	2014	Escalade ESV	Body	Instrument Cluster																																																															
4	2014	Escalade ESV	Body	Radio																																																															
4	2014	Escalade ESV	Body	Amplifier																																																															
4	2014	Escalade ESV	Body	Rear Audio Control Module																																																															
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																																															
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																																															
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																																															
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																															
4	2014	Escalade ESV	Body	HVAC Control Module																																																															
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																																															
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
4	2014	Escalade ESV	Body	Liftgate Control Module																																																												
4	2014	Escalade ESV	Body	Seat Memory Control Module																																																												
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																																												
4	2014	Escalade ESV	Body	Assist Step Control Module																																																												
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																																												
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																																												
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																																												
4	2014	Escalade ESV	Body	Parking Assist Control Module																																																												
4	2014	Escalade ESV	Body	Theft Deterrent Module																																																												
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																																												
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																																												
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																																												
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																																												
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																																												
4	2015	Escalade	Chassis	Electronic Brake Control Module																																																												
4	2015	Escalade	Chassis	Parking Brake Control Module																																																												
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																												
4	2015	Escalade	Chassis	Power Steering Control Module																																																												
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																												
4	2015	Escalade	Chassis	Suspension Control Module																																																												
4	2015	Escalade	Body	Body Control Module																																																												
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
4	2015	Escalade	Body	Passenger Presence Module																																																												
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																												
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																												
4	2015	Escalade	Body	Instrument Cluster																																																												
4	2015	Escalade	Body	Radio/HVAC Control																																																												
4	2015	Escalade	Body	Active Safety Control Module																																																												
4	2015	Escalade	Body	Video Processing Control Module																																																												
4	2015	Escalade	Body	Radio																																																												
4	2015	Escalade	Body	Amplifier																																																												
4	2015	Escalade	Body	Media Disc Player																																																												
4	2015	Escalade	Body	Human Machine Interface Control Module																																																												
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																																												
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																																												
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																																												
4	2015	Escalade	Body	HVAC Control Module																																																												
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																											
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																											
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																																											
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																																											
4	2015	Escalade	Body	Keyless Entry Control Module																																																											
4	2015	Escalade	Body	Assist Step Control Module																																																											
4	2015	Escalade	Body	Left Side Object Detection Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
4	2015	Escalade	Body	Parking Assist Control Module																																																												
4	2015	Escalade	Body	Frontview Camera Module																																																													
4	2015	Escalade	Body	Steering Column Lock Control Module																																																													
4	2015	Escalade	Body	Battery Energy Control Module																																																													
4	2015	Escalade	Body	Long Range Radar Sensor Module																																																													
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																																													
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																																													
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																													
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																													
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																													
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																													
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																																													
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																																													
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																													
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																																													
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																													
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																																													
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																																													
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																													
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																																													
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																													
4	2015	Escalade ESV	Chassis	Suspension Control Module																																																													
4	2015	Escalade ESV	Body	Body Control Module																																																													
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
4	2015	Escalade ESV	Body	Passenger Presence Module																																																													
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																													
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																													
4	2015	Escalade ESV	Body	Instrument Cluster																																																													
4	2015	Escalade ESV	Body	Radio/HVAC Control																																																													
4	2015	Escalade ESV	Body	Active Safety Control Module																																																													
4	2015	Escalade ESV	Body	Video Processing Control Module																																																													
4	2015	Escalade ESV	Body	Radio																																																													
4	2015	Escalade ESV	Body	Amplifier																																																													
4	2015	Escalade ESV	Body	Media Disc Player																																																													
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																																													
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																																													
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																																													
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																																													
4	2015	Escalade ESV	Body	HVAC Control Module																																																													
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																																													
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																																													
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																																													
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																																													
4	2015	Escalade ESV	Body	Assist Step Control Module																																																													
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																																													
4	2015	Escalade ESV	Body	Parking Assist Control Module																																																													
4	2015	Escalade ESV	Body	Frontview Camera Module																																																													
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																																												
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																												
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																												
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																												
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																												
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
4	2016	Escalade	Chassis	Electronic Brake Control Module																																																												
4	2016	Escalade	Chassis	Parking Brake Control Module																																																												
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																																												
4	2016	Escalade	Chassis	Power Steering Control Module																																																												
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																																												
4	2016	Escalade	Chassis	Suspension Control Module																																																												
4	2016	Escalade	Body	Body Control Module																																																												
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
4	2016	Escalade	Body	Passenger Presence Module																																																												
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																																												
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																																												
4	2016	Escalade	Body	Instrument Cluster																																																												
4	2016	Escalade	Body	Radio/HVAC Control																																																												
4	2016	Escalade	Body	Active Safety Control Module																																																												
4	2016	Escalade	Body	Video Processing Control Module																																																												
4	2016	Escalade	Body	Radio																																																												
4	2016	Escalade	Body	Amplifier																																																												
4	2016	Escalade	Body	Media Disc Player																																																												
4	2016	Escalade	Body	Human Machine Interface Control Module																																																												
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																																												
4	2016	Escalade	Body	HVAC Control Module																																																												
4	2016	Escalade	Body	Liftgate Control Module																																																												
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																																												
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																																												
4	2016	Escalade	Body	Keyless Entry Control Module																																																												
4	2016	Escalade	Body	Assist Step Control Module																																																												
4	2016	Escalade	Body	Left Side Object Detection Control Module																																																												
4	2016	Escalade	Body	Parking Assist Control Module																																																												
4	2016	Escalade	Body	Frontview Camera Module																																																												
4	2016	Escalade	Body	Steering Column Lock Control Module																																																												
4	2016	Escalade	Body	Long Range Radar Sensor Module																																																												
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																																												
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																																												
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																																												
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																																												
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																																												
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																																													
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																																													
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																																													
4	2016	Escalade ESV	Chassis	Suspension Control Module																																																													
4	2016	Escalade ESV	Body	Body Control Module																																																													
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
4	2016	Escalade ESV	Body	Passenger Presence Module																																																													
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																																													
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																																													
4	2016	Escalade ESV	Body	Instrument Cluster																																																													
4	2016	Escalade ESV	Body	Radio Control																																																													
4	2016	Escalade ESV	Body	HVAC Control																																																													
4	2016	Escalade ESV	Body	Active Safety Control Module																																																													
4	2016	Escalade ESV	Body	Video Processing Control Module																																																													
4	2016	Escalade ESV	Body	Radio																																																													
4	2016	Escalade ESV	Body	Amplifier																																																													
4	2016	Escalade ESV	Body	Media Disc Player																																																													
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																																													
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																																													
4	2016	Escalade ESV	Body	HVAC Control Module																																																													
4	2016	Escalade ESV	Body	Liftgate Control Module																																																													
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																																													
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																																													
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																																													
4	2016	Escalade ESV	Body	Assist Step Control Module																																																													
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																																													
4	2016	Escalade ESV	Body	Parking Assist Control Module																																																													
4	2016	Escalade ESV	Body	Frontview Camera Module																																																													
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																																													
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																																													
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																																													
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																																													
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																																													
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																																													
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																													
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																													
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																													
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																													
ALL	2004	Hearse	Chassis	DRP/ABS/TCS																																																													
ALL	2004	Hearse	Chassis	Magna Steer																																																													
ALL	2004	Hearse	Chassis	Rear Integration Module																																																													
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																																																													
ALL	2004	Hearse	Body	Amplifier (Delco)																																																													
ALL	2004	Hearse	Body	Dash Integration Module																																																													
ALL	2004	Hearse	Body	Driver Door Switch																																																													
ALL	2004	Hearse	Body	Driver Door Module																																																													
ALL	2004	Hearse	Body	Passenger Door Module																																																													
ALL	2004	Hearse	Body	Instrument Panel Cluster																																																													
ALL	2004	Hearse	Body	Instrument Panel Module																																																													
ALL	2004	Hearse	Body	Personalization																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
ALL	2004	Hearse	Body	Radio																																																														
ALL	2004	Hearse	Body	Rear Integration Module																																																															
ALL	2004	Hearse	Body	Remote Function Actuation																																																															
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																																																															
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																																																															
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																															
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																															
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																															
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																															
ALL	2004	Limousine	Chassis	DRP/ABS/TCS																																																															
ALL	2004	Limousine	Chassis	Magna Steer																																																															
ALL	2004	Limousine	Chassis	Rear Integration Module																																																															
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																																																															
ALL	2004	Limousine	Body	Amplifier (Delco)																																																															
ALL	2004	Limousine	Body	Dash Integration Module																																																															
ALL	2004	Limousine	Body	Driver Door Switch																																																															
ALL	2004	Limousine	Body	Driver Door Module																																																															
ALL	2004	Limousine	Body	Passenger Door Module																																																															
ALL	2004	Limousine	Body	Left Mid Door Module																																																															
ALL	2004	Limousine	Body	Left Rear Door Module																																																															
ALL	2004	Limousine	Body	Right Mid Door Module																																																															
ALL	2004	Limousine	Body	Right Rear Door Module																																																															
ALL	2004	Limousine	Body	Instrument Panel Cluster																																																															
ALL	2004	Limousine	Body	Instrument Panel Module																																																															
ALL	2004	Limousine	Body	Memory Seat Module																																																															
ALL	2004	Limousine	Body	Navigation Radio																																																															
ALL	2004	Limousine	Body	Personalization																																																															
ALL	2004	Limousine	Body	Radio																																																															
ALL	2004	Limousine	Body	Rear Climate Control Panel																																																															
ALL	2004	Limousine	Body	Rear Integration Module																																																															
ALL	2004	Limousine	Body	Remote Function Actuation																																																															
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																																																															
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																																																															
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																															
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																															
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																															
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																															
ALL	2005	Hearse	Chassis	DRP/ABS/TCS																																																															
ALL	2005	Hearse	Chassis	Magna Steer																																																															
ALL	2005	Hearse	Chassis	Rear Integration Module																																																															
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																																																															
ALL	2005	Hearse	Body	Amplifier (Delco)																																																															
ALL	2005	Hearse	Body	Dash Integration Module																																																															
ALL	2005	Hearse	Body	Driver Door Switch																																																															
ALL	2005	Hearse	Body	Driver Door Module																																																															
ALL	2005	Hearse	Body	Passenger Door Module																																																															
ALL	2005	Hearse	Body	Instrument Panel Cluster																																																															
ALL	2005	Hearse	Body	Instrument Panel Module																																																															
ALL	2005	Hearse	Body	Personalization																																																															
ALL	2005	Hearse	Body	Radio																																																															
ALL	2005	Hearse	Body	Rear Integration Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
ALL	2005	Hearse	Body	Remote Function Actuation																																																										
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																																										
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																																										
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																																										
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																																										
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																																										
ALL	2005	Limousine	Chassis	DRP/ABS/TCS																																																										
ALL	2005	Limousine	Chassis	Magna Steer																																																										
ALL	2005	Limousine	Chassis	Rear Integration Module																																																										
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																																																										
ALL	2005	Limousine	Body	Amplifier (Delco)																																																										
ALL	2005	Limousine	Body	Dash Integration Module																																																										
ALL	2005	Limousine	Body	Driver Door Switch																																																										
ALL	2005	Limousine	Body	Driver Door Module																																																										
ALL	2005	Limousine	Body	Passenger Door Module																																																										
ALL	2005	Limousine	Body	Left Mid Door Module																																																										
ALL	2005	Limousine	Body	Left Rear Door Module																																																										
ALL	2005	Limousine	Body	Right Mid Door Module																																																										
ALL	2005	Limousine	Body	Right Rear Door Module																																																										
ALL	2005	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2005	Limousine	Body	Instrument Panel Module																																																										
ALL	2005	Limousine	Body	Memory Seat Module																																																										
ALL	2005	Limousine	Body	Navigation Radio																																																										
ALL	2005	Limousine	Body	Personalization																																																										
ALL	2005	Limousine	Body	Radio																																																										
ALL	2005	Limousine	Body	Rear Climate Control Panel																																																										
ALL	2005	Limousine	Body	Rear Integration Module																																																										
ALL	2005	Limousine	Body	Remote Function Actuation																																																										
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																																										
ALL	2006	Hearse	Powertrain	Engine Control Module																																																										
ALL	2006	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2006	Hearse	Body	Amplifier (Bose)																																																										
ALL	2006	Hearse	Body	Body Control Module																																																										
ALL	2006	Hearse	Body	Digital Radio Receiver																																																										
ALL	2006	Hearse	Body	Driver Door Switch																																																										
ALL	2006	Hearse	Body	Driver Position Module																																																										
ALL	2006	Hearse	Body	HVAC Control Module																																																										
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2006	Hearse	Body	Passenger Door Switch																																																										
ALL	2006	Hearse	Body	Passenger Presence System																																																										
ALL	2006	Hearse	Body	Radio																																																										
ALL	2006	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	Hearse	Body	Theft Deterrent Module																																																										
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
ALL	2006	Limousine	Powertrain	Engine Control Module																																																										
ALL	2006	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2006	Limousine	Body	Amplifier (Bose)																																																										
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2006	Limousine	Body	Body Control Module																																																										
ALL	2006	Limousine	Body	Digital Radio Receiver																																																										
ALL	2006	Limousine	Body	Driver Door Switch																																																										
ALL	2006	Limousine	Body	Driver Position Module																																																										
ALL	2006	Limousine	Body	HVAC Control Module																																																										
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																																										
ALL	2006	Limousine	Body	Instrument Panel Cluster																																																										
ALL	2006	Limousine	Body	Passenger Door Switch																																																										
ALL	2006	Limousine	Body	Passenger Presence System																																																										
ALL	2006	Limousine	Body	Radio																																																										
ALL	2006	Limousine	Body	Rear Heated Seat Module																																																										
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																																										
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	Limousine	Body	Theft Deterrent Module																																																										
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																																										
ALL	2007	Hearse	Powertrain	Engine Control Module																																																										
ALL	2007	Hearse	Powertrain	Transmission Control Module																																																										
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																																										
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Hearse	Body	Amplifier (Bose)																																																										
ALL	2007	Hearse	Body	Body Control Module																																																										
ALL	2007	Hearse	Body	Digital Radio Receiver																																																										
ALL	2007	Hearse	Body	Driver Door Switch																																																										
ALL	2007	Hearse	Body	Driver Position Module																																																										
ALL	2007	Hearse	Body	HVAC Control Module																																																										
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																																										
ALL	2007	Hearse	Body	Instrument Panel Cluster																																																										
ALL	2007	Hearse	Body	Passenger Door Switch																																																										
ALL	2007	Hearse	Body	Passenger Presence System																																																										
ALL	2007	Hearse	Body	Radio																																																										
ALL	2007	Hearse	Body	Rear Heated Seat Module																																																										
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	Hearse	Body	Theft Deterrent Module																																																										
ALL	2007	Limousine	Powertrain	Engine Control Module																																																										
ALL	2007	Limousine	Powertrain	Transmission Control Module																																																										
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																																										
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																																										
ALL	2007	Limousine	Body	Amplifier (Bose)																																																										
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																																										
ALL	2007	Limousine	Body	Body Control Module																																																										
ALL	2007	Limousine	Body	Digital Radio Receiver																																																										
ALL	2007	Limousine	Body	Driver Door Switch																																																										
ALL	2007	Limousine	Body	Driver Position Module																																																										
ALL	2007	Limousine	Body	HVAC Control Module																																																										
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
ALL	2007	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2007	Limousine	Body	Passenger Door Switch																																																												
ALL	2007	Limousine	Body	Passenger Presence System																																																												
ALL	2007	Limousine	Body	Radio																																																												
ALL	2007	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2007	Limousine	Body	Theft Deterrent Module																																																												
ALL	2008	Hearse	Powertrain	Engine Control Module																																																												
ALL	2008	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2008	Hearse	Body	Amplifier (Bose)																																																												
ALL	2008	Hearse	Body	Body Control Module																																																												
ALL	2008	Hearse	Body	Climate Control Seat Module																																																												
ALL	2008	Hearse	Body	Digital Radio Receiver																																																												
ALL	2008	Hearse	Body	Driver Door Switch																																																												
ALL	2008	Hearse	Body	Driver Position Module																																																												
ALL	2008	Hearse	Body	HVAC Control Module																																																												
ALL	2008	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2008	Hearse	Body	Passenger Door Switch																																																												
ALL	2008	Hearse	Body	Passenger Presence System																																																												
ALL	2008	Hearse	Body	Radio																																																												
ALL	2008	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2008	Hearse	Body	Theft Deterrent Module																																																												
ALL	2008	Limousine	Powertrain	Engine Control Module																																																													
ALL	2008	Limousine	Powertrain	Transmission Control Module																																																													
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																																												
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																																												
ALL	2008	Limousine	Body	Amplifier (Bose)																																																												
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																																												
ALL	2008	Limousine	Body	Body Control Module																																																												
ALL	2008	Limousine	Body	Climate Control Seat Module																																																												
ALL	2008	Limousine	Body	Digital Radio Receiver																																																												
ALL	2008	Limousine	Body	Driver Door Switch																																																												
ALL	2008	Limousine	Body	Driver Position Module																																																												
ALL	2008	Limousine	Body	HVAC Control Module																																																												
ALL	2008	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2008	Limousine	Body	Passenger Door Switch																																																												
ALL	2008	Limousine	Body	Passenger Presence System																																																												
ALL	2008	Limousine	Body	Radio																																																												
ALL	2008	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2008	Limousine	Body	Theft Deterrent Module																																																												
ALL	2009	Hearse	Powertrain	Engine Control Module																																																													
ALL	2009	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2009	Hearse	Body	Amplifier (Bose)																																																												
ALL	2009	Hearse	Body	Body Control Module																																																												
ALL	2009	Hearse	Body	Climate Control Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
ALL	2009	Hearse	Body	Digital Radio Receiver																																																											
ALL	2009	Hearse	Body	Driver Door Switch																																																												
ALL	2009	Hearse	Body	Driver Position Module																																																												
ALL	2009	Hearse	Body	HVAC Control Module																																																												
ALL	2009	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2009	Hearse	Body	Passenger Door Switch																																																												
ALL	2009	Hearse	Body	Passenger Presence System																																																												
ALL	2009	Hearse	Body	Radio																																																												
ALL	2009	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2009	Hearse	Body	Theft Deterrent Module																																																												
ALL	2009	Limousine	Powertrain	Engine Control Module																																																												
ALL	2009	Limousine	Powertrain	Transmission Control Module																																																												
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																																												
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																																												
ALL	2009	Limousine	Body	Amplifier (Bose)																																																												
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																																												
ALL	2009	Limousine	Body	Body Control Module																																																												
ALL	2009	Limousine	Body	Climate Control Seat Module																																																												
ALL	2009	Limousine	Body	Digital Radio Receiver																																																												
ALL	2009	Limousine	Body	Driver Door Switch																																																												
ALL	2009	Limousine	Body	Driver Position Module																																																												
ALL	2009	Limousine	Body	HVAC Control Module																																																												
ALL	2009	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2009	Limousine	Body	Passenger Door Switch																																																												
ALL	2009	Limousine	Body	Passenger Presence System																																																												
ALL	2009	Limousine	Body	Radio																																																												
ALL	2009	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2009	Limousine	Body	Theft Deterrent Module																																																												
ALL	2010	Hearse	Powertrain	Engine Control Module																																																												
ALL	2010	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2010	Hearse	Body	Amplifier (Bose)																																																												
ALL	2010	Hearse	Body	Body Control Module																																																												
ALL	2010	Hearse	Body	Climate Control Seat Module																																																												
ALL	2010	Hearse	Body	Digital Radio Receiver																																																												
ALL	2010	Hearse	Body	Driver Door Switch																																																												
ALL	2010	Hearse	Body	Driver Position Module																																																												
ALL	2010	Hearse	Body	HVAC Control Module																																																												
ALL	2010	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2010	Hearse	Body	Passenger Door Switch																																																												
ALL	2010	Hearse	Body	Passenger Presence System																																																												
ALL	2010	Hearse	Body	Radio																																																												
ALL	2010	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2010	Hearse	Body	Theft Deterrent Module																																																												
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																																												
ALL	2010	Limousine	Powertrain	Engine Control Module																																																												
ALL	2010	Limousine	Powertrain	Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																																											
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																																												
ALL	2010	Limousine	Body	Amplifier (Bose)																																																												
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																																												
ALL	2010	Limousine	Body	Body Control Module																																																												
ALL	2010	Limousine	Body	Climate Control Seat Module																																																												
ALL	2010	Limousine	Body	Digital Radio Receiver																																																												
ALL	2010	Limousine	Body	Driver Door Switch																																																												
ALL	2010	Limousine	Body	Driver Position Module																																																												
ALL	2010	Limousine	Body	HVAC Control Module																																																												
ALL	2010	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2010	Limousine	Body	Passenger Door Switch																																																												
ALL	2010	Limousine	Body	Passenger Presence System																																																												
ALL	2010	Limousine	Body	Radio																																																												
ALL	2010	Limousine	Body	Rear Heated Seat Module																																																												
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																																												
ALL	2010	Limousine	Body	Theft Deterrent Module																																																												
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																																												
ALL	2011	Hearse	Powertrain	Engine Control Module																																																												
ALL	2011	Hearse	Powertrain	Transmission Control Module																																																												
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																																												
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																																												
ALL	2011	Hearse	Body	Amplifier (Bose)																																																												
ALL	2011	Hearse	Body	Body Control Module																																																												
ALL	2011	Hearse	Body	Climate Control Seat Module																																																												
ALL	2011	Hearse	Body	Digital Radio Receiver																																																												
ALL	2011	Hearse	Body	Driver Door Switch																																																												
ALL	2011	Hearse	Body	Driver Position Module																																																												
ALL	2011	Hearse	Body	HVAC Control Module																																																												
ALL	2011	Hearse	Body	Instrument Panel Cluster																																																												
ALL	2011	Hearse	Body	Passenger Door Switch																																																												
ALL	2011	Hearse	Body	Passenger Presence System																																																												
ALL	2011	Hearse	Body	Radio																																																												
ALL	2011	Hearse	Body	Rear Heated Seat Module																																																												
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																																												
ALL	2011	Hearse	Body	Theft Deterrent Module																																																												
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																																												
ALL	2011	Limousine	Powertrain	Engine Control Module																																																												
ALL	2011	Limousine	Powertrain	Transmission Control Module																																																												
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																																												
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																																												
ALL	2011	Limousine	Body	Amplifier (Bose)																																																												
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																																												
ALL	2011	Limousine	Body	Body Control Module																																																												
ALL	2011	Limousine	Body	Climate Control Seat Module																																																												
ALL	2011	Limousine	Body	Digital Radio Receiver																																																												
ALL	2011	Limousine	Body	Driver Door Switch																																																												
ALL	2011	Limousine	Body	Driver Position Module																																																												
ALL	2011	Limousine	Body	HVAC Control Module																																																												
ALL	2011	Limousine	Body	Instrument Panel Cluster																																																												
ALL	2011	Limousine	Body	Passenger Door Switch																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
ALL	2011	Limousine	Body	Passenger Presence System																																																																
ALL	2011	Limousine	Body	Radio																																																																
ALL	2011	Limousine	Body	Rear Heated Seat Module																																																																
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																																																
ALL	2011	Limousine	Body	Theft Deterrent Module																																																																
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																																																

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																								
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
C	2004	ALL	Chassis	ABS Over 8600 GVW																																								
C	2004	ALL	Chassis	ESC																																								
C	2004	ALL	Chassis	Rear Wheel Steering																																								
C	2004	ALL	Chassis	Tire Pressure Monitor																																								
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																								
C	2004	ALL	Chassis	VSES																																								
C	2004	ALL	Body	Amplifier (Bose)																																								
C	2004	ALL	Body	Body Control Module																																								
C	2004	ALL	Body	CD Changer																																								
C	2004	ALL	Body	Chime																																								
C	2004	ALL	Body	Driver Door Module																																								
C	2004	ALL	Body	Driver Seat Module																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																								
C	2004	ALL	Body	Heating and Air Conditioning Manual																																								
C	2004	ALL	Body	Instrument Panel Cluster																																								
C	2004	ALL	Body	OnStar																																								
C	2004	ALL	Body	Passenger Door Module																																								
C	2004	ALL	Body	Passenger Presence System																																								
C	2004	ALL	Body	Base Radio																																								
C	2004	ALL	Body	Uplevel Radio																																								
C	2004	ALL	Body	Navigation Radio																																								
C	2004	ALL	Body	Rear Aux. Climate Module																																								
C	2004	ALL	Body	Rear HVAC																																								
C	2004	ALL	Body	Rear Seat Audio																																								
C	2004	ALL	Body	Rear Seat Entertainment																																								
C	2004	ALL	Body	Supplemental Inflatable Restraint																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																								
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																								
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
C	2005	ALL	Chassis	ABS Over 8600 GVW																																								
C	2005	ALL	Chassis	ESC																																								
C	2005	ALL	Chassis	Rear Wheel Steering																																								
C	2005	ALL	Chassis	Tire Pressure Monitor																																								
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																								
C	2005	ALL	Chassis	VSES																																								
C	2005	ALL	Body	Amplifier (Bose)																																								
C	2005	ALL	Body	Body Control Module																																								
C	2005	ALL	Body	CD Changer																																								
C	2005	ALL	Body	Chime																																								
C	2005	ALL	Body	Disc Player and Video Display																																								
C	2005	ALL	Body	Driver Door Module																																								
C	2005	ALL	Body	Driver Seat Module																																								
C	2005	ALL	Body	Generator Battery Control Module																																								
C	2005	ALL	Body	Heating and Air Conditioning Auto																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																								
C	2005	ALL	Body	Heating and Air Conditioning Manual																																								
C	2005	ALL	Body	Instrument Panel Cluster																																								
C	2005	ALL	Body	Passenger Door Module																																								
C	2005	ALL	Body	Passenger Presence System																																								
C	2005	ALL	Body	Base Radio																																								
C	2005	ALL	Body	Uplevel Radio																																								
C	2005	ALL	Body	Navigation Radio																																								
C	2005	ALL	Body	Rear Aux. Climate Module																																								
C	2005	ALL	Body	Rear HVAC																																								
C	2005	ALL	Body	Rear Seat Audio																																								
C	2005	ALL	Body	Remote Function Actuation																																								
C	2005	ALL	Body	Supplemental Inflatable Restraint																																								
C	2005	ALL	Body	Vehicle Comm. Interface Module																																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																								
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																								
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
C	2006	ALL	Chassis	ABS Over 8600 GVW																																								
C	2006	ALL	Chassis	ESC																																								
C	2006	ALL	Chassis	Tire Pressure Monitor																																								
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																								
C	2006	ALL	Chassis	VSES																																								
C	2006	ALL	Body	Amplifier (Bose)																																								
C	2006	ALL	Body	Body Control Module																																								
C	2006	ALL	Body	CD Changer																																								
C	2006	ALL	Body	Chime																																								
C	2006	ALL	Body	Disc Player and Video Display																																								
C	2006	ALL	Body	Driver Door Module																																								
C	2006	ALL	Body	Driver Seat Module																																								
C	2006	ALL	Body	Generator Battery Control Module																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																								
C	2006	ALL	Body	Heating and Air Conditioning Manual																																								
C	2006	ALL	Body	Instrument Panel Cluster																																								
C	2006	ALL	Body	Passenger Door Module																																								
C	2006	ALL	Body	Passenger Presence System																																								
C	2006	ALL	Body	Base Radio																																								
C	2006	ALL	Body	Uplevel Radio																																								
C	2006	ALL	Body	Navigation Radio																																								
C	2006	ALL	Body	Rear Aux. Climate Module																																								
C	2006	ALL	Body	Rear HVAC																																								
C	2006	ALL	Body	Rear Seat Audio																																								
C	2006	ALL	Body	Supplemental Inflatable Restraint																																								
C	2006	ALL	Body	Vehicle Comm. Interface Module																																								
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
C	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
C	2007	ALL	Chassis	Electronic Brake Control Module																																								
C	2007	ALL	Chassis	Electronic Suspension Control																																								
C	2007	ALL	Body	Amplifier (Bose)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2007	ALL	Body	Assist Step Controller																																								
C	2007	ALL	Body	Body Control Module																																								
C	2007	ALL	Body	Body Control Module (aux.)																																								
C	2007	ALL	Body	Digital Radio Receiver																																								
C	2007	ALL	Body	Driver Door Switch																																								
C	2007	ALL	Body	HVAC Control Module																																								
C	2007	ALL	Body	Inside Rear View Mirror Module																																								
C	2007	ALL	Body	Instrument Panel Cluster																																								
C	2007	ALL	Body	Lift Gate Module																																								
C	2007	ALL	Body	Memory Seat Module																																								
C	2007	ALL	Body	Park Assist Module																																								
C	2007	ALL	Body	Passenger Door Switch																																								
C	2007	ALL	Body	Passenger Presence System																																								
C	2007	ALL	Body	Radio																																								
C	2007	ALL	Body	Rear Heated Seat Module																																								
C	2007	ALL	Body	Rear HVAC/RSA																																								
C	2007	ALL	Body	Rollover Sensor																																								
C	2007	ALL	Body	Supplemental Inflatable Restraint																																								
C	2007	ALL	Body	Theft Deterrent Module																																								
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																								
C	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
C	2008	ALL	Chassis	Electronic Brake Control Module																																								
C	2008	ALL	Chassis	Electronic Suspension Control																																								
C	2008	ALL	Chassis	Trailer Brake Control Module																																								
C	2008	ALL	Body	Amplifier (Bose)																																								
C	2008	ALL	Body	Assist Step Controller																																								
C	2008	ALL	Body	Body Control Module																																								
C	2008	ALL	Body	Body Control Module (aux.)																																								
C	2008	ALL	Body	Digital Radio Receiver																																								
C	2008	ALL	Body	Driver Door Switch																																								
C	2008	ALL	Body	HVAC Control Module																																								
C	2008	ALL	Body	Inside Rear View Mirror Module																																								
C	2008	ALL	Body	Instrument Panel Cluster																																								
C	2008	ALL	Body	Lift Gate Module																																								
C	2008	ALL	Body	Memory Seat Module																																								
C	2008	ALL	Body	Park Assist Module																																								
C	2008	ALL	Body	Passenger Door Switch																																								
C	2008	ALL	Body	Passenger Presence System																																								
C	2008	ALL	Body	Radio																																								
C	2008	ALL	Body	Rear Heated Seat Module																																								
C	2008	ALL	Body	Rear HVAC/RSA																																								
C	2008	ALL	Body	Rollover Sensor																																								
C	2008	ALL	Body	Supplemental Inflatable Restraint																																								
C	2008	ALL	Body	Theft Deterrent Module																																								
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2009	ALL	Chassis	Electronic Brake Control Module																																								
C	2009	ALL	Chassis	Electronic Suspension Control																																								
C	2009	ALL	Chassis	Trailer Brake Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2009	ALL	Body	Amplifier (Bose)																																								
C	2009	ALL	Body	Assist Step Controller																																								
C	2009	ALL	Body	Body Control Module																																								
C	2009	ALL	Body	Body Control Module (aux.)																																								
C	2009	ALL	Body	Digital Radio Receiver																																								
C	2009	ALL	Body	Driver Door Switch																																								
C	2009	ALL	Body	HVAC Control Module																																								
C	2009	ALL	Body	Inside Rear View Mirror Module																																								
C	2009	ALL	Body	Instrument Panel Cluster																																								
C	2009	ALL	Body	Left Side Object Detection Module																																								
C	2009	ALL	Body	Lift Gate Module																																								
C	2009	ALL	Body	Memory Seat Module																																								
C	2009	ALL	Body	Park Assist Module																																								
C	2009	ALL	Body	Passenger Door Switch																																								
C	2009	ALL	Body	Passenger Presence System																																								
C	2009	ALL	Body	Radio																																								
C	2009	ALL	Body	Rear Heated Seat Module																																								
C	2009	ALL	Body	Rear HVAC/RSA																																								
C	2009	ALL	Body	Right Side Object Detection Module																																								
C	2009	ALL	Body	Rollover Sensor																																								
C	2009	ALL	Body	Supplemental Inflatable Restraint																																								
C	2009	ALL	Body	Theft Deterrent Module																																								
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
C	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2010	ALL	Chassis	Electronic Brake Control Module																																								
C	2010	ALL	Chassis	Electronic Suspension Control																																								
C	2010	ALL	Chassis	FPCM with Trailer Brake Control																																								
C	2010	ALL	Body	Amplifier (Bose)																																								
C	2010	ALL	Body	Assist Step Controller																																								
C	2010	ALL	Body	Body Control Module																																								
C	2010	ALL	Body	Body Control Module (aux.)																																								
C	2010	ALL	Body	Digital Radio Receiver																																								
C	2010	ALL	Body	Driver Door Switch																																								
C	2010	ALL	Body	HVAC Control Module																																								
C	2010	ALL	Body	Inside Rear View Mirror Module																																								
C	2010	ALL	Body	Instrument Panel Cluster																																								
C	2010	ALL	Body	Left Side Object Detection Module																																								
C	2010	ALL	Body	Lift Gate Module																																								
C	2010	ALL	Body	Memory Seat Module																																								
C	2010	ALL	Body	Park Assist Module																																								
C	2010	ALL	Body	Passenger Door Switch																																								
C	2010	ALL	Body	Passenger Presence System																																								
C	2010	ALL	Body	Radio																																								
C	2010	ALL	Body	Rear Heated Seat Module																																								
C	2010	ALL	Body	Rear HVAC/RSA																																								
C	2010	ALL	Body	Right Side Object Detection Module																																								
C	2010	ALL	Body	Supplemental Inflatable Restraint																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2010	ALL	Body	Theft Deterrent Module																																								
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								
E	2004	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																								
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																								
E	2004	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																								
E	2004	ALL	Chassis	DRP/ABS/TCS/VSES																																								
E	2004	ALL	Chassis	Electronic Suspension Control																																								
E	2004	ALL	Chassis	Tire Pressure Monitor																																								
E	2004	ALL	Chassis	VES																																								
E	2004	ALL	Body	Amplifier (Bose)																																								
E	2004	ALL	Body	Amplifier (Delco)																																								
E	2004	ALL	Body	Climate Control Panel																																								
E	2004	ALL	Body	Dash Integration Module																																								
E	2004	ALL	Body	Disc Player and Video Display																																								
E	2004	ALL	Body	Driver Door Switch																																								
E	2004	ALL	Body	Driver Door Module																																								
E	2004	ALL	Body	Passenger Door Module																																								
E	2004	ALL	Body	Left Rear Door Module																																								
E	2004	ALL	Body	Right Rear Door Module																																								
E	2004	ALL	Body	Lt. Headlamp Leveling Module																																								
E	2004	ALL	Body	Rt. Headlamp Leveling Mod.																																								
E	2004	ALL	Body	Instrument Panel Cluster																																								
E	2004	ALL	Body	Memory Seat Module																																								
E	2004	ALL	Body	OnStar																																								
E	2004	ALL	Body	Personalization																																								
E	2004	ALL	Body	Base Radio																																								
E	2004	ALL	Body	Navigation Radio																																								
E	2004	ALL	Body	Rear Integration Module																																								
E	2004	ALL	Body	Rear Seat Module																																								
E	2004	ALL	Body	Remote Function Actuation																																								
E	2004	ALL	Body	Supplemental Inflatable Restraint																																								
E	2004	ALL	Body	TV Antenna Module																																								
E	2004	ALL	Body	Vehicle Theft Deterrent																																								
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								
E	2005	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																								
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																								
E	2005	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																								
E	2005	ALL	Chassis	DRP/ABS/TCS/VSES																																								
E	2005	ALL	Chassis	Electronic Suspension Control																																								
E	2005	ALL	Chassis	Tire Pressure Monitor																																								
E	2005	ALL	Chassis	VES																																								
E	2005	ALL	Body	Amplifier (Bose)																																								
E	2005	ALL	Body	Amplifier (Delco)																																								
E	2005	ALL	Body	Climate Control Panel																																								
E	2005	ALL	Body	Dash Integration Module																																								
E	2005	ALL	Body	Disc Player and Video Display																																								
E	2005	ALL	Body	Driver Door Switch																																								
E	2005	ALL	Body	Driver Door Module																																								
E	2005	ALL	Body	Passenger Door Module																																								
E	2005	ALL	Body	Left Rear Door Module																																								
E	2005	ALL	Body	Right Rear Door Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
E	2005	ALL	Body	Lt. Headlamp Leveling Module																																								
E	2005	ALL	Body	Rt. Headlamp Leveling Mod.																																								
E	2005	ALL	Body	Instrument Panel Cluster																																								
E	2005	ALL	Body	Memory Seat Module																																								
E	2005	ALL	Body	Personalization																																								
E	2005	ALL	Body	Base Radio																																								
E	2005	ALL	Body	Navigation Radio																																								
E	2005	ALL	Body	Rear Integration Module																																								
E	2005	ALL	Body	Rear Seat Module																																								
E	2005	ALL	Body	Remote Function Actuation																																								
E	2005	ALL	Body	Supplemental Inflatable Restraint																																								
E	2005	ALL	Body	TV Antenna Module																																								
E	2005	ALL	Body	Vehicle Comm. Interface Module																																								
E	2005	ALL	Body	Vehicle Theft Deterrent																																								
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								
E	2006	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																								
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																								
E	2006	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																								
E	2006	ALL	Chassis	DRP/ABS/TCS/VSES																																								
E	2006	ALL	Chassis	Electronic Suspension Control																																								
E	2006	ALL	Chassis	Tire Pressure Monitor																																								
E	2006	ALL	Chassis	VES																																								
E	2006	ALL	Body	Amplifier (Bose)																																								
E	2006	ALL	Body	Amplifier (Delco)																																								
E	2006	ALL	Body	Climate Control Panel																																								
E	2006	ALL	Body	Dash Integration Module																																								
E	2006	ALL	Body	Disc Player and Video Display																																								
E	2006	ALL	Body	Driver Door Switch																																								
E	2006	ALL	Body	Driver Door Module																																								
E	2006	ALL	Body	Passenger Door Module																																								
E	2006	ALL	Body	Left Rear Door Module																																								
E	2006	ALL	Body	Right Rear Door Module																																								
E	2006	ALL	Body	Lt. Headlamp Leveling Module																																								
E	2006	ALL	Body	Rt. Headlamp Leveling Mod.																																								
E	2006	ALL	Body	Instrument Panel Cluster																																								
E	2006	ALL	Body	Lift Gate Module																																								
E	2006	ALL	Body	Memory Seat Module																																								
E	2006	ALL	Body	Personalization																																								
E	2006	ALL	Body	Base Radio																																								
E	2006	ALL	Body	Navigation Radio																																								
E	2006	ALL	Body	Rear Integration Module																																								
E	2006	ALL	Body	Rear Seat Module																																								
E	2006	ALL	Body	Remote Function Actuation																																								
E	2006	ALL	Body	Supplemental Inflatable Restraint																																								
E	2006	ALL	Body	Vehicle Comm. Interface Module																																								
E	2006	ALL	Body	Vehicle Theft Deterrent																																								
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								
E	2007	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																								
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																								
E	2007	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																								
E	2007	ALL	Chassis	Electronic Brake Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Thefflock LED
E	2007	ALL	Chassis	Electronic Suspension Control																																								
E	2007	ALL	Body	Amplifier (Bose)																																								
E	2007	ALL	Body	Body Control Module																																								
E	2007	ALL	Body	Body Control Module (aux.)																																								
E	2007	ALL	Body	Digital Radio Receiver																																								
E	2007	ALL	Body	Driver Door Switch																																								
E	2007	ALL	Body	Lt. Headlamp Leveling Module																																								
E	2007	ALL	Body	Rt. Headlamp Leveling Mod.																																								
E	2007	ALL	Body	HVAC Control Module																																								
E	2007	ALL	Body	Instrument Panel Cluster																																								
E	2007	ALL	Body	Lift Gate Module																																								
E	2007	ALL	Body	Memory Seat Module																																								
E	2007	ALL	Body	Park Assist Module																																								
E	2007	ALL	Body	Passenger Door Switch																																								
E	2007	ALL	Body	Passenger Presence System																																								
E	2007	ALL	Body	Radio																																								
E	2007	ALL	Body	Rear HVAC/RSA																																								
E	2007	ALL	Body	Rear Seat Module																																								
E	2007	ALL	Body	Remote Control Door Lock Receiver																																								
E	2007	ALL	Body	Rollover Sensor																																								
E	2007	ALL	Body	Supplemental Inflatable Restraint																																								
E	2007	ALL	Body	Theft Deterrent Module																																								
E	2007	ALL	Body	TV Antenna Module																																								
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								
E	2008	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																								
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																								
E	2008	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																								
E	2008	ALL	Chassis	Electronic Brake Control Module																																								
E	2008	ALL	Chassis	Electronic Suspension Control																																								
E	2008	ALL	Body	Amplifier (Bose)																																								
E	2008	ALL	Body	Body Control Module																																								
E	2008	ALL	Body	Body Control Module (aux.)																																								
E	2008	ALL	Body	Digital Radio Receiver																																								
E	2008	ALL	Body	Driver Door Switch																																								
E	2008	ALL	Body	Lt. Headlamp Leveling Module																																								
E	2008	ALL	Body	Rt. Headlamp Leveling Mod.																																								
E	2008	ALL	Body	HVAC Control Module																																								
E	2008	ALL	Body	Instrument Panel Cluster																																								
E	2008	ALL	Body	Lift Gate Module																																								
E	2008	ALL	Body	Memory Seat Module																																								
E	2008	ALL	Body	Park Assist Module																																								
E	2008	ALL	Body	Passenger Door Switch																																								
E	2008	ALL	Body	Passenger Presence System																																								
E	2008	ALL	Body	Radio																																								
E	2008	ALL	Body	Rear HVAC/RSA																																								
E	2008	ALL	Body	Rear Seat Module																																								
E	2008	ALL	Body	Remote Control Door Lock Receiver																																								
E	2008	ALL	Body	Rollover Sensor																																								
E	2008	ALL	Body	Supplemental Inflatable Restraint																																								
E	2008	ALL	Body	Theft Deterrent Module																																								
E	2008	ALL	Body	TV Antenna Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								
E	2009	ALL	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																								
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Engine Control Module																																								
E	2009	ALL	Powertrain	(A)4.6L V8 LH2 Transmission Control Module																																								
E	2009	ALL	Chassis	Electronic Brake Control Module																																								
E	2009	ALL	Chassis	Electronic Suspension Control																																								
E	2009	ALL	Body	Amplifier (Bose)																																								
E	2009	ALL	Body	Body Control Module																																								
E	2009	ALL	Body	Body Control Module (aux.)																																								
E	2009	ALL	Body	Digital Radio Receiver																																								
E	2009	ALL	Body	Driver Door Switch																																								
E	2009	ALL	Body	Lt. Headlamp Leveling Module																																								
E	2009	ALL	Body	Rt. Headlamp Leveling Mod.																																								
E	2009	ALL	Body	HVAC Control Module																																								
E	2009	ALL	Body	Instrument Panel Cluster																																								
E	2009	ALL	Body	Lift Gate Module																																								
E	2009	ALL	Body	Memory Seat Module																																								
E	2009	ALL	Body	Park Assist Module																																								
E	2009	ALL	Body	Passenger Door Switch																																								
E	2009	ALL	Body	Passenger Presence System																																								
E	2009	ALL	Body	Radio																																								
E	2009	ALL	Body	Rear HVAC/RSA																																								
E	2009	ALL	Body	Rear Seat Module																																								
E	2009	ALL	Body	Remote Control Door Lock Receiver																																								
E	2009	ALL	Body	Rollover Sensor																																								
E	2009	ALL	Body	Supplemental Inflatable Restraint																																								
E	2009	ALL	Body	Theft Deterrent Module																																								
E	2009	ALL	Body	TV Antenna Module																																								
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																								
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
K	2004	ALL	Chassis	ABS Over 8600 GVW																																								
K	2004	ALL	Chassis	ESC																																								
K	2004	ALL	Chassis	Rear Wheel Steering																																								
K	2004	ALL	Chassis	Tire Pressure Monitor																																								
K	2004	ALL	Chassis	VSES																																								
K	2004	ALL	Body	Amplifier (Bose)																																								
K	2004	ALL	Body	Body Control Module																																								
K	2004	ALL	Body	CD Changer																																								
K	2004	ALL	Body	Chime																																								
K	2004	ALL	Body	Driver Door Module																																								
K	2004	ALL	Body	Driver Seat Module																																								
K	2004	ALL	Body	Heating and Air Conditioning Auto																																								
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																								
K	2004	ALL	Body	Heating and Air Conditioning Manual																																								
K	2004	ALL	Body	Instrument Panel Cluster																																								
K	2004	ALL	Body	OnStar																																								
K	2004	ALL	Body	Passenger Door Module																																								
K	2004	ALL	Body	Passenger Presence System																																								
K	2004	ALL	Body	Base Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2004	ALL	Body	Uplevel Radio																																								
K	2004	ALL	Body	Navigation Radio																																								
K	2004	ALL	Body	Rear Aux. Climate Module																																								
K	2004	ALL	Body	Rear HVAC																																								
K	2004	ALL	Body	Rear Seat Audio																																								
K	2004	ALL	Body	Rear Seat Entertainment																																								
K	2004	ALL	Body	Supplemental Inflatable Restraint																																								
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																								
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																								
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
K	2005	ALL	Chassis	ABS Over 8600 GVW																																								
K	2005	ALL	Chassis	ESC																																								
K	2005	ALL	Chassis	Rear Wheel Steering																																								
K	2005	ALL	Chassis	Tire Pressure Monitor																																								
K	2005	ALL	Chassis	VSES																																								
K	2005	ALL	Body	Amplifier (Bose)																																								
K	2005	ALL	Body	Body Control Module																																								
K	2005	ALL	Body	CD Changer																																								
K	2005	ALL	Body	Chime																																								
K	2005	ALL	Body	Disc Player and Video Display																																								
K	2005	ALL	Body	Driver Door Module																																								
K	2005	ALL	Body	Driver Seat Module																																								
K	2005	ALL	Body	Generator Battery Control Module																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																								
K	2005	ALL	Body	Heating and Air Conditioning Manual																																								
K	2005	ALL	Body	Instrument Panel Cluster																																								
K	2005	ALL	Body	Passenger Door Module																																								
K	2005	ALL	Body	Passenger Presence System																																								
K	2005	ALL	Body	Base Radio																																								
K	2005	ALL	Body	Uplevel Radio																																								
K	2005	ALL	Body	Navigation Radio																																								
K	2005	ALL	Body	Rear Aux. Climate Module																																								
K	2005	ALL	Body	Rear HVAC																																								
K	2005	ALL	Body	Rear Seat Audio																																								
K	2005	ALL	Body	Remote Function Actuation																																								
K	2005	ALL	Body	Supplemental Inflatable Restraint																																								
K	2005	ALL	Body	Vehicle Comm. Interface Module																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Drum																																								
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW Disk																																								
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
K	2006	ALL	Chassis	ABS Over 8600 GVW																																								
K	2006	ALL	Chassis	ESC																																								
K	2006	ALL	Chassis	Tire Pressure Monitor																																								
K	2006	ALL	Chassis	VSES																																								
K	2006	ALL	Body	Amplifier (Bose)																																								
K	2006	ALL	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2006	ALL	Body	CD Changer																																								
K	2006	ALL	Body	Chime																																								
K	2006	ALL	Body	Disc Player and Video Display																																								
K	2006	ALL	Body	Driver Door Module																																								
K	2006	ALL	Body	Driver Seat Module																																								
K	2006	ALL	Body	Generator Battery Control Module																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																								
K	2006	ALL	Body	Heating and Air Conditioning Manual																																								
K	2006	ALL	Body	Instrument Panel Cluster																																								
K	2006	ALL	Body	Passenger Door Module																																								
K	2006	ALL	Body	Passenger Presence System																																								
K	2006	ALL	Body	Base Radio																																								
K	2006	ALL	Body	Uplevel Radio																																								
K	2006	ALL	Body	Navigation Radio																																								
K	2006	ALL	Body	Rear Aux. Climate Module																																								
K	2006	ALL	Body	Rear HVAC																																								
K	2006	ALL	Body	Rear Seat Audio																																								
K	2006	ALL	Body	Supplemental Inflatable Restraint																																								
K	2006	ALL	Body	Vehicle Comm. Interface Module																																								
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
K	2007	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
K	2007	ALL	Chassis	Electronic Brake Control Module																																								
K	2007	ALL	Chassis	Electronic Suspension Control																																								
K	2007	ALL	Body	Amplifier (Bose)																																								
K	2007	ALL	Body	Assist Step Controller																																								
K	2007	ALL	Body	Body Control Module																																								
K	2007	ALL	Body	Body Control Module (aux.)																																								
K	2007	ALL	Body	Digital Radio Receiver																																								
K	2007	ALL	Body	Driver Door Switch																																								
K	2007	ALL	Body	HVAC Control Module																																								
K	2007	ALL	Body	Inside Rear View Mirror Module																																								
K	2007	ALL	Body	Instrument Panel Cluster																																								
K	2007	ALL	Body	Lift Gate Module																																								
K	2007	ALL	Body	Memory Seat Module																																								
K	2007	ALL	Body	Park Assist Module																																								
K	2007	ALL	Body	Passenger Door Switch																																								
K	2007	ALL	Body	Passenger Presence System																																								
K	2007	ALL	Body	Radio																																								
K	2007	ALL	Body	Rear Heated Seat Module																																								
K	2007	ALL	Body	Rear HVAC/RSA																																								
K	2007	ALL	Body	Rollover Sensor																																								
K	2007	ALL	Body	Supplemental Inflatable Restraint																																								
K	2007	ALL	Body	Theft Deterrent Module																																								
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																								
K	2008	ALL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
K	2008	ALL	Chassis	Electronic Brake Control Module																																								
K	2008	ALL	Chassis	Electronic Suspension Control																																								
K	2008	ALL	Chassis	Trailer Brake Control Module																																								
K	2008	ALL	Body	Amplifier (Bose)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2008	ALL	Body	Assist Step Controller																																								
K	2008	ALL	Body	Body Control Module																																								
K	2008	ALL	Body	Body Control Module (aux.)																																								
K	2008	ALL	Body	Digital Radio Receiver																																								
K	2008	ALL	Body	Driver Door Switch																																								
K	2008	ALL	Body	HVAC Control Module																																								
K	2008	ALL	Body	Inside Rear View Mirror Module																																								
K	2008	ALL	Body	Instrument Panel Cluster																																								
K	2008	ALL	Body	Lift Gate Module																																								
K	2008	ALL	Body	Memory Seat Module																																								
K	2008	ALL	Body	Park Assist Module																																								
K	2008	ALL	Body	Passenger Door Switch																																								
K	2008	ALL	Body	Passenger Presence System																																								
K	2008	ALL	Body	Radio																																								
K	2008	ALL	Body	Rear Heated Seat Module																																								
K	2008	ALL	Body	Rear HVAC/RSA																																								
K	2008	ALL	Body	Rollover Sensor																																								
K	2008	ALL	Body	Supplemental Inflatable Restraint																																								
K	2008	ALL	Body	Theft Deterrent Module																																								
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2009	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2009	ALL	Chassis	Electronic Brake Control Module																																								
K	2009	ALL	Chassis	Electronic Suspension Control																																								
K	2009	ALL	Chassis	Trailer Brake Control Module																																								
K	2009	ALL	Body	Amplifier (Bose)																																								
K	2009	ALL	Body	Assist Step Controller																																								
K	2009	ALL	Body	Body Control Module																																								
K	2009	ALL	Body	Body Control Module (aux.)																																								
K	2009	ALL	Body	Digital Radio Receiver																																								
K	2009	ALL	Body	Driver Door Switch																																								
K	2009	ALL	Body	HVAC Control Module																																								
K	2009	ALL	Body	Inside Rear View Mirror Module																																								
K	2009	ALL	Body	Instrument Panel Cluster																																								
K	2009	ALL	Body	Left Side Object Detection Module																																								
K	2009	ALL	Body	Lift Gate Module																																								
K	2009	ALL	Body	Memory Seat Module																																								
K	2009	ALL	Body	Park Assist Module																																								
K	2009	ALL	Body	Passenger Door Switch																																								
K	2009	ALL	Body	Passenger Presence System																																								
K	2009	ALL	Body	Radio																																								
K	2009	ALL	Body	Rear Heated Seat Module																																								
K	2009	ALL	Body	Rear HVAC/RSA																																								
K	2009	ALL	Body	Right Side Object Detection Module																																								
K	2009	ALL	Body	Rollover Sensor																																								
K	2009	ALL	Body	Supplemental Inflatable Restraint																																								
K	2009	ALL	Body	Theft Deterrent Module																																								
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
K	2010	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2010	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2010	ALL	Chassis	Electronic Brake Control Module																																								
K	2010	ALL	Chassis	Electronic Suspension Control																																								
K	2010	ALL	Chassis	FPCM with Trailer Brake Control																																								
K	2010	ALL	Body	Amplifier (Bose)																																								
K	2010	ALL	Body	Assist Step Controller																																								
K	2010	ALL	Body	Body Control Module																																								
K	2010	ALL	Body	Body Control Module (aux.)																																								
K	2010	ALL	Body	Digital Radio Receiver																																								
K	2010	ALL	Body	Driver Door Switch																																								
K	2010	ALL	Body	HVAC Control Module																																								
K	2010	ALL	Body	Inside Rear View Mirror Module																																								
K	2010	ALL	Body	Instrument Panel Cluster																																								
K	2010	ALL	Body	Left Side Object Detection Module																																								
K	2010	ALL	Body	Lift Gate Module																																								
K	2010	ALL	Body	Memory Seat Module																																								
K	2010	ALL	Body	Park Assist Module																																								
K	2010	ALL	Body	Passenger Door Switch																																								
K	2010	ALL	Body	Passenger Presence System																																								
K	2010	ALL	Body	Radio																																								
K	2010	ALL	Body	Rear Heated Seat Module																																								
K	2010	ALL	Body	Rear HVAC/RSA																																								
K	2010	ALL	Body	Right Side Object Detection Module																																								
K	2010	ALL	Body	Supplemental Inflatable Restraint																																								
K	2010	ALL	Body	Theft Deterrent Module																																								
N	2010	SRX	Powertrain	(4) 2.8L LAU Engine Control Module																																								
N	2010	SRX	Powertrain	(4) 2.8L LAU Fuel Pump Control Module																																								
N	2010	SRX	Powertrain	(4) 2.8L LAU Transmission Control Module																																								
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																								
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																								
N	2010	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																								
N	2010	SRX	Powertrain	Rear Differential Clutch Control Module																																								
N	2010	SRX	Chassis	Electronic Brake Control Module																																								
N	2010	SRX	Chassis	Parking Brake Control Module																																								
N	2010	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																								
N	2010	SRX	Chassis	Steering Wheel Angle Sensor Module																																								
N	2010	SRX	Chassis	Suspension Control Module																																								
N	2010	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																								
N	2010	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																								
N	2010	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
N	2010	SRX	Body	Passenger Presence Module																																								
N	2010	SRX	Body	Instrument Cluster																																								
N	2010	SRX	Body	Headlamp Control Module																																								
N	2010	SRX	Body	Trailer Interface Control Module																																								
N	2010	SRX	Body	Radio																																								
N	2010	SRX	Body	Rear Audio Control Module																																								
N	2010	SRX	Body	Digital Radio Receiver Control Module																																								
N	2010	SRX	Body	Multimedia Player Interface Module																																								
N	2010	SRX	Body	Mobile Telephone Control Module																																								
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 8																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
N	2010	SRX	Body	Telematics Communication Interface Control Module Version 10																																								
N	2010	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																								
N	2010	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																								
N	2010	SRX	Body	Liftgate Control Module																																								
N	2010	SRX	Body	Seat Memory Control Module																																								
N	2010	SRX	Body	Front Seat Heating Control Module																																								
N	2010	SRX	Body	Rear Seat Heating Control Module																																								
N	2010	SRX	Body	Keyless Entry Type Without Passive Entry																																								
N	2010	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																								
N	2010	SRX	Body	Parking Assist Control Module																																								
N	2010	SRX	Body	Steering Column Lock Control Module																																								
N	2011	SRX	Powertrain	(6) 2.8L LAU Engine Control Module																																								
N	2011	SRX	Powertrain	(6) 2.8L LAU Fuel Pump Control Module																																								
N	2011	SRX	Powertrain	(6) 2.8L LAU Transmission Control Module																																								
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Engine Control Module																																								
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																								
N	2011	SRX	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																								
N	2011	SRX	Powertrain	Rear Differential Clutch Control Module																																								
N	2011	SRX	Chassis	Electronic Brake Control Module																																								
N	2011	SRX	Chassis	Parking Brake Control Module																																								
N	2011	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																								
N	2011	SRX	Chassis	Steering Wheel Angle Sensor Module																																								
N	2011	SRX	Chassis	Suspension Control Module																																								
N	2011	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																								
N	2011	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																								
N	2011	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
N	2011	SRX	Body	Passenger Presence Module																																								
N	2011	SRX	Body	Instrument Cluster																																								
N	2011	SRX	Body	Headlamp Control Module																																								
N	2011	SRX	Body	Trailer Interface Control Module																																								
N	2011	SRX	Body	Radio																																								
N	2011	SRX	Body	Rear Audio Control Module																																								
N	2011	SRX	Body	Digital Radio Receiver Control Module																																								
N	2011	SRX	Body	Multimedia Player Interface Module																																								
N	2011	SRX	Body	Mobile Telephone Control Module																																								
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 9																																								
N	2011	SRX	Body	Telematics Communication Interface Control Module Version 10																																								
N	2011	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																								
N	2011	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																								
N	2011	SRX	Body	Liftgate Control Module																																								
N	2011	SRX	Body	Seat Memory Control Module																																								
N	2011	SRX	Body	Front Seat Heating Control Module																																								
N	2011	SRX	Body	Rear Seat Heating Control Module																																								
N	2011	SRX	Body	Keyless Entry Type Without Passive Entry																																								
N	2011	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																								
N	2011	SRX	Body	Parking Assist Control Module																																								
N	2011	SRX	Body	Steering Column Lock Control Module																																								
N	2012	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																								
N	2012	SRX	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																								
N	2012	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
N	2012	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
N	2012	SRX	Powertrain	(3) 3.6L LFX Fuel Pump Control Module																																								
N	2012	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
N	2012	SRX	Powertrain	Rear Differential Clutch Control Module																																								
N	2012	SRX	Chassis	Electronic Brake Control Module																																								
N	2012	SRX	Chassis	Parking Brake Control Module																																								
N	2012	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																								
N	2012	SRX	Chassis	Steering Wheel Angle Sensor Module																																								
N	2012	SRX	Chassis	Suspension Control Module																																								
N	2012	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																								
N	2012	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																								
N	2012	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
N	2012	SRX	Body	Passenger Presence Module																																								
N	2012	SRX	Body	Instrument Cluster																																								
N	2012	SRX	Body	Headlamp Control Module																																								
N	2012	SRX	Body	Trailer Interface Control Module																																								
N	2012	SRX	Body	Radio																																								
N	2012	SRX	Body	Rear Audio Control Module																																								
N	2012	SRX	Body	Digital Radio Receiver Control Module																																								
N	2012	SRX	Body	Multimedia Player Interface Module																																								
N	2012	SRX	Body	Mobile Telephone Control Module																																								
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 9																																								
N	2012	SRX	Body	Telematics Communication Interface Control Module Version 10																																								
N	2012	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																								
N	2012	SRX	Body	HVAC Auto Control Single Zone (CJ4)																																								
N	2012	SRX	Body	Liftgate Control Module																																								
N	2012	SRX	Body	Seat Memory Control Module																																								
N	2012	SRX	Body	Front Seat Heating Control Module																																								
N	2012	SRX	Body	Rear Seat Heating Control Module																																								
N	2012	SRX	Body	Keyless Entry Type Without Passive Entry																																								
N	2012	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																								
N	2012	SRX	Body	Parking Assist Control Module																																								
N	2012	SRX	Body	Steering Column Lock Control Module																																								
N	2013	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																								
N	2013	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
N	2013	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																								
N	2013	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
N	2013	SRX	Powertrain	Rear Differential Clutch Control Module																																								
N	2013	SRX	Chassis	Electronic Brake Control Module																																								
N	2013	SRX	Chassis	Parking Brake Control Module																																								
N	2013	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																								
N	2013	SRX	Chassis	Steering Wheel Angle Sensor Module																																								
N	2013	SRX	Chassis	Suspension Control Module																																								
N	2013	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																								
N	2013	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																								
N	2013	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
N	2013	SRX	Body	Passenger Presence Module																																								
N	2013	SRX	Body	Instrument Cluster																																								
N	2013	SRX	Body	Radio/HVAC Control																																								
N	2013	SRX	Body	Active Safety Control Module																																								
N	2013	SRX	Body	Headlamp Control Module																																								
N	2013	SRX	Body	Trailer Interface Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
N	2013	SRX	Body	Radio																																								
N	2013	SRX	Body	Amplifier																																								
N	2013	SRX	Body	Media Disc Player																																								
N	2013	SRX	Body	Human Machine Interface Control Module																																								
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 9																																								
N	2013	SRX	Body	Telematics Communication Interface Control Module Version 10																																								
N	2013	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																								
N	2013	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																								
N	2013	SRX	Body	Liftgate Control Module																																								
N	2013	SRX	Body	Seat Memory Control Module																																								
N	2013	SRX	Body	Rear Seat Heating Control Module																																								
N	2013	SRX	Body	Keyless Entry Type Without Passive Entry																																								
N	2013	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																								
N	2013	SRX	Body	Right Side Object Detection Control Module																																								
N	2013	SRX	Body	Left Side Object Detection Control Module																																								
N	2013	SRX	Body	Parking Assist Control Module																																								
N	2013	SRX	Body	Frontview Camera Module																																								
N	2013	SRX	Body	Steering Column Lock Control Module																																								
N	2013	SRX	Body	Long Range Radar Sensor Module																																								
N	2013	SRX	Body	Left Front Short Range Radar Sensor Module																																								
N	2013	SRX	Body	Right Front Short Range Radar Sensor Module																																								
N	2013	SRX	Body	Rear Short Range Radar Sensor Module																																								
N	2014	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																								
N	2014	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
N	2014	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																								
N	2014	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
N	2014	SRX	Powertrain	Rear Differential Clutch Control Module																																								
N	2014	SRX	Chassis	Electronic Brake Control Module																																								
N	2014	SRX	Chassis	Parking Brake Control Module																																								
N	2014	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																								
N	2014	SRX	Chassis	Steering Wheel Angle Sensor Module																																								
N	2014	SRX	Chassis	Suspension Control Module																																								
N	2014	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																								
N	2014	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																								
N	2014	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
N	2014	SRX	Body	Passenger Presence Module																																								
N	2014	SRX	Body	Instrument Cluster																																								
N	2014	SRX	Body	Radio/HVAC Control																																								
N	2014	SRX	Body	Active Safety Control Module																																								
N	2014	SRX	Body	Headlamp Control Module																																								
N	2014	SRX	Body	Trailer Interface Control Module																																								
N	2014	SRX	Body	Radio																																								
N	2014	SRX	Body	Amplifier																																								
N	2014	SRX	Body	Media Disc Player																																								
N	2014	SRX	Body	Human Machine Interface Control Module																																								
N	2014	SRX	Body	Navigation Control Module																																								
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																								
N	2014	SRX	Body	Telematics Communication Interface Control Module Version 10																																								
N	2014	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																								
N	2014	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																								
N	2014	SRX	Body	Liftgate Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
N	2014	SRX	Body	Seat Memory Control Module - Driver																																								
N	2014	SRX	Body	Rear Seat Heating Control Module																																								
N	2014	SRX	Body	Keyless Entry Type Without Passive Entry																																								
N	2014	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																								
N	2014	SRX	Body	Right Side Object Detection Control Module																																								
N	2014	SRX	Body	Left Side Object Detection Control Module																																								
N	2014	SRX	Body	Parking Assist Control Module																																								
N	2014	SRX	Body	Frontview Camera Module																																								
N	2014	SRX	Body	Steering Column Lock Control Module																																								
N	2014	SRX	Body	Long Range Radar Sensor Module																																								
N	2014	SRX	Body	Left Front Short Range Radar Sensor Module																																								
N	2014	SRX	Body	Right Front Short Range Radar Sensor Module																																								
N	2014	SRX	Body	Rear Short Range Radar Sensor Module																																								
N	2015	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																								
N	2015	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
N	2015	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																								
N	2015	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
N	2015	SRX	Powertrain	Rear Differential Clutch Control Module																																								
N	2015	SRX	Chassis	Electronic Brake Control Module																																								
N	2015	SRX	Chassis	Parking Brake Control Module																																								
N	2015	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																								
N	2015	SRX	Chassis	Steering Wheel Angle Sensor Module																																								
N	2015	SRX	Chassis	Suspension Control Module																																								
N	2015	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																								
N	2015	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																								
N	2015	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
N	2015	SRX	Body	Passenger Presence Module																																								
N	2015	SRX	Body	Instrument Cluster																																								
N	2015	SRX	Body	Radio/HVAC Control																																								
N	2015	SRX	Body	Active Safety Control Module																																								
N	2015	SRX	Body	Headlamp Control Module																																								
N	2015	SRX	Body	Trailer Interface Control Module																																								
N	2015	SRX	Body	Radio																																								
N	2015	SRX	Body	Amplifier																																								
N	2015	SRX	Body	Rear Audio Control Module																																								
N	2015	SRX	Body	Media Disc Player																																								
N	2015	SRX	Body	Human Machine Interface Control Module																																								
N	2015	SRX	Body	Navigation Control Module																																								
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																								
N	2015	SRX	Body	Telematics Communication Interface Control Module Version 10																																								
N	2015	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																								
N	2015	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																								
N	2015	SRX	Body	Liftgate Control Module																																								
N	2015	SRX	Body	Seat Memory Control Module - Driver																																								
N	2015	SRX	Body	Rear Seat Heating Control Module																																								
N	2015	SRX	Body	Keyless Entry Type Without Passive Entry																																								
N	2015	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																								
N	2015	SRX	Body	Right Side Object Detection Control Module																																								
N	2015	SRX	Body	Left Side Object Detection Control Module																																								
N	2015	SRX	Body	Parking Assist Control Module																																								
N	2015	SRX	Body	Frontview Camera Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
N	2015	SRX	Body	Steering Column Lock Control Module																																								
N	2015	SRX	Body	Long Range Radar Sensor Module																																								
N	2015	SRX	Body	Left Front Short Range Radar Sensor Module																																								
N	2015	SRX	Body	Right Front Short Range Radar Sensor Module																																								
N	2015	SRX	Body	Rear Short Range Radar Sensor Module																																								
N	2016	SRX	Powertrain	(5) 3.0L LFW Engine Control Module																																								
N	2016	SRX	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
N	2016	SRX	Powertrain	(3) 3.6L LFX Engine Control Module																																								
N	2016	SRX	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
N	2016	SRX	Powertrain	Rear Differential Clutch Control Module																																								
N	2016	SRX	Chassis	Electronic Brake Control Module																																								
N	2016	SRX	Chassis	Parking Brake Control Module																																								
N	2016	SRX	Chassis	Multi-Axis Acceleration Sensor Module																																								
N	2016	SRX	Chassis	Steering Wheel Angle Sensor Module																																								
N	2016	SRX	Chassis	Suspension Control Module																																								
N	2016	SRX	Body	Body Control Module Headlamp Type Halogen (T4A TT4)																																								
N	2016	SRX	Body	Body Control Module Headlamp Type High Intensity Discharge (T4F TT2 TT6 TT7 TT8)																																								
N	2016	SRX	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
N	2016	SRX	Body	Passenger Presence Module																																								
N	2016	SRX	Body	Instrument Cluster Enhanced Driver Info Center (UDD)																																								
N	2016	SRX	Body	Instrument Cluster Full Screen Display (UDV)																																								
N	2016	SRX	Body	Radio/HVAC Control																																								
N	2016	SRX	Body	Active Safety Control Module																																								
N	2016	SRX	Body	Headlamp Control Module																																								
N	2016	SRX	Body	Trailer Interface Control Module																																								
N	2016	SRX	Body	Radio																																								
N	2016	SRX	Body	Amplifier																																								
N	2016	SRX	Body	Rear Audio Control Module																																								
N	2016	SRX	Body	Media Disc Player																																								
N	2016	SRX	Body	Human Machine Interface Control Module																																								
N	2016	SRX	Body	Navigation Control Module																																								
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 9.7																																								
N	2016	SRX	Body	Telematics Communication Interface Control Module Version 10																																								
N	2016	SRX	Body	HVAC Auto Control Dual Zone (CJ2)																																								
N	2016	SRX	Body	HVAC Auto Control Tri Zone (CJ4)																																								
N	2016	SRX	Body	Liftgate Control Module																																								
N	2016	SRX	Body	Seat Memory Control Module - Driver																																								
N	2016	SRX	Body	Rear Seat Heating Control Module																																								
N	2016	SRX	Body	Keyless Entry Type Without Passive Entry																																								
N	2016	SRX	Body	Keyless Entry Type Extended Range Passive Entry (ATH)																																								
N	2016	SRX	Body	Right Side Object Detection Control Module																																								
N	2016	SRX	Body	Left Side Object Detection Control Module																																								
N	2016	SRX	Body	Parking Assist Control Module																																								
N	2016	SRX	Body	Frontview Camera Module																																								
N	2016	SRX	Body	Steering Column Lock Control Module																																								
N	2016	SRX	Body	Long Range Radar Sensor Module																																								
N	2016	SRX	Body	Left Front Short Range Radar Sensor Module																																								
N	2016	SRX	Body	Right Front Short Range Radar Sensor Module																																								
N	2016	SRX	Body	Rear Short Range Radar Sensor Module																																								
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
3	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
3	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
3	2011	ALL	Chassis	Electronic Brake Control Module																																								
3	2011	ALL	Chassis	Electronic Suspension Control																																								
3	2011	ALL	Chassis	FPCM with Trailer Brake Control																																								
3	2011	ALL	Body	Amplifier (Bose)																																								
3	2011	ALL	Body	Assist Step Controller																																								
3	2011	ALL	Body	Body Control Module																																								
3	2011	ALL	Body	Body Control Module (aux.)																																								
3	2011	ALL	Body	Digital Radio Receiver																																								
3	2011	ALL	Body	Driver Door Switch																																								
3	2011	ALL	Body	HVAC Control Module																																								
3	2011	ALL	Body	Inside Rear View Mirror Module																																								
3	2011	ALL	Body	Instrument Panel Cluster																																								
3	2011	ALL	Body	Left Side Object Detection Module																																								
3	2011	ALL	Body	Lift Gate Module																																								
3	2011	ALL	Body	Memory Seat Module																																								
3	2011	ALL	Body	Park Assist Module																																								
3	2011	ALL	Body	Passenger Door Switch																																								
3	2011	ALL	Body	Passenger Presence System																																								
3	2011	ALL	Body	Radio																																								
3	2011	ALL	Body	Rear Heated Seat Module																																								
3	2011	ALL	Body	Rear HVAC/RSA																																								
3	2011	ALL	Body	Right Side Object Detection Module																																								
3	2011	ALL	Body	Supplemental Inflatable Restraint																																								
3	2011	ALL	Body	Theft Deterrent Module																																								
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
3	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
3	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
3	2012	ALL	Chassis	Electronic Brake Control Module																																								
3	2012	ALL	Chassis	Electronic Suspension Control																																								
3	2012	ALL	Chassis	FPCM with Trailer Brake Control																																								
3	2012	ALL	Body	Amplifier (Bose)																																								
3	2012	ALL	Body	Assist Step Controller																																								
3	2012	ALL	Body	Body Control Module																																								
3	2012	ALL	Body	Body Control Module (aux.)																																								
3	2012	ALL	Body	Driver Door Switch																																								
3	2012	ALL	Body	HVAC Control Module																																								
3	2012	ALL	Body	Inside Rear View Mirror Module																																								
3	2012	ALL	Body	Instrument Panel Cluster																																								
3	2012	ALL	Body	Left Side Object Detection Module																																								
3	2012	ALL	Body	Lift Gate Module																																								
3	2012	ALL	Body	Memory Seat Module																																								
3	2012	ALL	Body	Park Assist Module																																								
3	2012	ALL	Body	Passenger Door Switch																																								
3	2012	ALL	Body	Passenger Presence System																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
3	2012	ALL	Body	Radio																																								
3	2012	ALL	Body	Rear Heated Seat Module																																								
3	2012	ALL	Body	Rear HVAC/RSA																																								
3	2012	ALL	Body	Right Side Object Detection Module																																								
3	2012	ALL	Body	Supplemental Inflatable Restraint																																								
3	2012	ALL	Body	Theft Deterrent Module																																								
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
3	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
3	2013	ALL	Chassis	Electronic Brake Control Module																																								
3	2013	ALL	Chassis	Electronic Suspension Control																																								
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																								
3	2013	ALL	Chassis	FPCM with Trailer Brake Control																																								
3	2013	ALL	Body	Amplifier (Bose)																																								
3	2013	ALL	Body	Assist Step Controller																																								
3	2013	ALL	Body	Body Control Module																																								
3	2013	ALL	Body	Body Control Module (aux.)																																								
3	2013	ALL	Body	Driver Door Switch																																								
3	2013	ALL	Body	HVAC Control Module																																								
3	2013	ALL	Body	Inside Rear View Mirror Module																																								
3	2013	ALL	Body	Instrument Panel Cluster																																								
3	2013	ALL	Body	Left Side Object Detection Module																																								
3	2013	ALL	Body	Lift Gate Module																																								
3	2013	ALL	Body	Memory Seat Module																																								
3	2013	ALL	Body	Park Assist Module																																								
3	2013	ALL	Body	Passenger Door Switch																																								
3	2013	ALL	Body	Passenger Presence System																																								
3	2013	ALL	Body	Radio																																								
3	2013	ALL	Body	Rear Heated Seat Module																																								
3	2013	ALL	Body	Rear HVAC/RSA																																								
3	2013	ALL	Body	Right Side Object Detection Module																																								
3	2013	ALL	Body	Supplemental Inflatable Restraint																																								
3	2013	ALL	Body	Theft Deterrent Module																																								
3	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																								
3	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																								
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																								
3	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																								
3	2014	Escalade	Chassis	Electronic Brake Control Module																																								
3	2014	Escalade	Chassis	Suspension Control Module																																								
3	2014	Escalade	Body	Body Control Module																																								
3	2014	Escalade	Body	Auxiliary Body Control Module																																								
3	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
3	2014	Escalade	Body	Passenger Presence Module																																								
3	2014	Escalade	Body	Instrument Cluster																																								
3	2014	Escalade	Body	Radio																																								
3	2014	Escalade	Body	Amplifier																																								
3	2014	Escalade	Body	Rear Audio Control Module																																								
3	2014	Escalade	Body	Digital Radio Receiver Control Module																																								
3	2014	Escalade	Body	Personal Audio Link Control Module																																								
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																								
3	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
3	2014	Escalade	Body	HVAC Control Module																																								
3	2014	Escalade	Body	Driver Door Switch Panel Control Module																																								
3	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																								
3	2014	Escalade	Body	Liftgate Control Module																																								
3	2014	Escalade	Body	Seat Memory Control Module																																								
3	2014	Escalade	Body	Rear Seat Heating Control Module																																								
3	2014	Escalade	Body	Assist Step Control Module																																								
3	2014	Escalade	Body	Right Side Object Detection Control Module																																								
3	2014	Escalade	Body	Left Side Object Detection Control Module																																								
3	2014	Escalade	Body	Remote Control Door Lock Receiver																																								
3	2014	Escalade	Body	Parking Assist Control Module																																								
3	2014	Escalade	Body	Theft Deterrent Module																																								
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																								
3	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																								
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																								
3	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																								
3	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																								
3	2014	Escalade ESV	Chassis	Suspension Control Module																																								
3	2014	Escalade ESV	Body	Body Control Module																																								
3	2014	Escalade ESV	Body	Auxiliary Body Control Module																																								
3	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
3	2014	Escalade ESV	Body	Passenger Presence Module																																								
3	2014	Escalade ESV	Body	Instrument Cluster																																								
3	2014	Escalade ESV	Body	Radio																																								
3	2014	Escalade ESV	Body	Amplifier																																								
3	2014	Escalade ESV	Body	Rear Audio Control Module																																								
3	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																								
3	2014	Escalade ESV	Body	Personal Audio Link Control Module																																								
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																								
3	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																								
3	2014	Escalade ESV	Body	HVAC Control Module																																								
3	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																								
3	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																								
3	2014	Escalade ESV	Body	Liftgate Control Module																																								
3	2014	Escalade ESV	Body	Seat Memory Control Module																																								
3	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																								
3	2014	Escalade ESV	Body	Assist Step Control Module																																								
3	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																								
3	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																								
3	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																								
3	2014	Escalade ESV	Body	Parking Assist Control Module																																								
3	2014	Escalade ESV	Body	Theft Deterrent Module																																								
3	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																								
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
3	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
3	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																								
3	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																								
3	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																								
3	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
3	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
3	2015	Escalade	Powertrain	Drive Motor Control Module 1																																								
3	2015	Escalade	Powertrain	Drive Motor Control Module 2																																								
3	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																								
3	2015	Escalade	Chassis	Electronic Brake Control Module																																								
3	2015	Escalade	Chassis	Parking Brake Control Module																																								
3	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																								
3	2015	Escalade	Chassis	Power Steering Control Module																																								
3	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																								
3	2015	Escalade	Chassis	Suspension Control Module																																								
3	2015	Escalade	Body	Body Control Module																																								
3	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
3	2015	Escalade	Body	Passenger Presence Module																																								
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																								
3	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																								
3	2015	Escalade	Body	Instrument Cluster																																								
3	2015	Escalade	Body	Radio/HVAC Control																																								
3	2015	Escalade	Body	Active Safety Control Module																																								
3	2015	Escalade	Body	Video Processing Control Module																																								
3	2015	Escalade	Body	Radio																																								
3	2015	Escalade	Body	Amplifier																																								
3	2015	Escalade	Body	Media Disc Player																																								
3	2015	Escalade	Body	Human Machine Interface Control Module																																								
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																								
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																								
3	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																								
3	2015	Escalade	Body	HVAC Control Module																																								
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																								
3	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																								
3	2015	Escalade	Body	Seat Memory Control Module - Passenger																																								
3	2015	Escalade	Body	Seat Memory Control Module - Driver																																								
3	2015	Escalade	Body	Keyless Entry Control Module																																								
3	2015	Escalade	Body	Assist Step Control Module																																								
3	2015	Escalade	Body	Left Side Object Detection Control Module																																								
3	2015	Escalade	Body	Parking Assist Control Module																																								
3	2015	Escalade	Body	Frontview Camera Module																																								
3	2015	Escalade	Body	Steering Column Lock Control Module																																								
3	2015	Escalade	Body	Battery Energy Control Module																																								
3	2015	Escalade	Body	Long Range Radar Sensor Module																																								
3	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																								
3	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																								
3	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																								
3	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																								
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																								
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
3	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
3	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																								
3	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																								
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																								
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
3	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
3	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
3	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																								
3	2015	Escalade ESV	Chassis	Parking Brake Control Module																																								
3	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																								
3	2015	Escalade ESV	Chassis	Power Steering Control Module																																								
3	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																								
3	2015	Escalade ESV	Chassis	Suspension Control Module																																								
3	2015	Escalade ESV	Body	Body Control Module																																								
3	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
3	2015	Escalade ESV	Body	Passenger Presence Module																																								
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																								
3	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																								
3	2015	Escalade ESV	Body	Instrument Cluster																																								
3	2015	Escalade ESV	Body	Radio/HVAC Control																																								
3	2015	Escalade ESV	Body	Active Safety Control Module																																								
3	2015	Escalade ESV	Body	Video Processing Control Module																																								
3	2015	Escalade ESV	Body	Radio																																								
3	2015	Escalade ESV	Body	Amplifier																																								
3	2015	Escalade ESV	Body	Media Disc Player																																								
3	2015	Escalade ESV	Body	Human Machine Interface Control Module																																								
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																								
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																								
3	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																								
3	2015	Escalade ESV	Body	HVAC Control Module																																								
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																								
3	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																								
3	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																								
3	2015	Escalade ESV	Body	Keyless Entry Control Module																																								
3	2015	Escalade ESV	Body	Assist Step Control Module																																								
3	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																								
3	2015	Escalade ESV	Body	Parking Assist Control Module																																								
3	2015	Escalade ESV	Body	Frontview Camera Module																																								
3	2015	Escalade ESV	Body	Steering Column Lock Control Module																																								
3	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																								
3	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																								
3	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																								
3	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																								
3	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																								
3	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																								
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
3	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
3	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
3	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
3	2016	Escalade	Chassis	Electronic Brake Control Module																																								
3	2016	Escalade	Chassis	Parking Brake Control Module																																								
3	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																								
3	2016	Escalade	Chassis	Power Steering Control Module																																								
3	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																								
3	2016	Escalade	Chassis	Suspension Control Module																																								
3	2016	Escalade	Body	Body Control Module																																								
3	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
3	2016	Escalade	Body	Passenger Presence Module																																								
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																								
3	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																								
3	2016	Escalade	Body	Instrument Cluster																																								
3	2016	Escalade	Body	Radio/HVAC Control																																								
3	2016	Escalade	Body	Active Safety Control Module																																								
3	2016	Escalade	Body	Video Processing Control Module																																								
3	2016	Escalade	Body	Radio																																								
3	2016	Escalade	Body	Amplifier																																								
3	2016	Escalade	Body	Media Disc Player																																								
3	2016	Escalade	Body	Human Machine Interface Control Module																																								
3	2016	Escalade	Body	Telematics Communication Interface Control Module																																								
3	2016	Escalade	Body	HVAC Control Module																																								
3	2016	Escalade	Body	Liftgate Control Module																																								
3	2016	Escalade	Body	Seat Memory Control Module - Passenger																																								
3	2016	Escalade	Body	Seat Memory Control Module - Driver																																								
3	2016	Escalade	Body	Keyless Entry Control Module																																								
3	2016	Escalade	Body	Assist Step Control Module																																								
3	2016	Escalade	Body	Left Side Object Detection Control Module																																								
3	2016	Escalade	Body	Parking Assist Control Module																																								
3	2016	Escalade	Body	Frontview Camera Module																																								
3	2016	Escalade	Body	Steering Column Lock Control Module																																								
3	2016	Escalade	Body	Long Range Radar Sensor Module																																								
3	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																								
3	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																								
3	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																								
3	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																								
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																								
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
3	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
3	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
3	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
3	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																								
3	2016	Escalade ESV	Chassis	Parking Brake Control Module																																								
3	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																								
3	2016	Escalade ESV	Chassis	Power Steering Control Module																																								
3	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																								
3	2016	Escalade ESV	Chassis	Suspension Control Module																																								
3	2016	Escalade ESV	Body	Body Control Module																																								
3	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
3	2016	Escalade ESV	Body	Passenger Presence Module																																								
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																								
3	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																								
3	2016	Escalade ESV	Body	Instrument Cluster																																								
3	2016	Escalade ESV	Body	Radio Control																																								
3	2016	Escalade ESV	Body	HVAC Control																																								
3	2016	Escalade ESV	Body	Active Safety Control Module																																								
3	2016	Escalade ESV	Body	Video Processing Control Module																																								
3	2016	Escalade ESV	Body	Radio																																								
3	2016	Escalade ESV	Body	Amplifier																																								
3	2016	Escalade ESV	Body	Media Disc Player																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
3	2016	Escalade ESV	Body	Human Machine Interface Control Module																																								
3	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																								
3	2016	Escalade ESV	Body	HVAC Control Module																																								
3	2016	Escalade ESV	Body	Liftgate Control Module																																								
3	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																								
3	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																								
3	2016	Escalade ESV	Body	Keyless Entry Control Module																																								
3	2016	Escalade ESV	Body	Assist Step Control Module																																								
3	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																								
3	2016	Escalade ESV	Body	Parking Assist Control Module																																								
3	2016	Escalade ESV	Body	Frontview Camera Module																																								
3	2016	Escalade ESV	Body	Steering Column Lock Control Module																																								
3	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																								
3	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																								
3	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																								
3	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																								
3	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																								
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
4	2011	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
4	2011	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
4	2011	ALL	Chassis	Electronic Brake Control Module																																								
4	2011	ALL	Chassis	Electronic Suspension Control																																								
4	2011	ALL	Chassis	FPCM with Trailer Brake Control																																								
4	2011	ALL	Body	Amplifier (Bose)																																								
4	2011	ALL	Body	Assist Step Controller																																								
4	2011	ALL	Body	Body Control Module																																								
4	2011	ALL	Body	Body Control Module (aux.)																																								
4	2011	ALL	Body	Driver Door Switch																																								
4	2011	ALL	Body	HVAC Control Module																																								
4	2011	ALL	Body	Inside Rear View Mirror Module																																								
4	2011	ALL	Body	Instrument Panel Cluster																																								
4	2011	ALL	Body	Left Side Object Detection Module																																								
4	2011	ALL	Body	Lift Gate Module																																								
4	2011	ALL	Body	Memory Seat Module																																								
4	2011	ALL	Body	Park Assist Module																																								
4	2011	ALL	Body	Passenger Door Switch																																								
4	2011	ALL	Body	Passenger Presence System																																								
4	2011	ALL	Body	Radio																																								
4	2011	ALL	Body	Rear Heated Seat Module																																								
4	2011	ALL	Body	Rear HVAC/RSA																																								
4	2011	ALL	Body	Right Side Object Detection Module																																								
4	2011	ALL	Body	Supplemental Inflatable Restraint																																								
4	2011	ALL	Body	Theft Deterrent Module																																								
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
4	2012	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
4	2012	ALL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
4	2012	ALL	Chassis	Electronic Brake Control Module																																								
4	2012	ALL	Chassis	Electronic Suspension Control																																								
4	2012	ALL	Chassis	FPCM with Trailer Brake Control																																								
4	2012	ALL	Body	Amplifier (Bose)																																								
4	2012	ALL	Body	Assist Step Controller																																								
4	2012	ALL	Body	Body Control Module																																								
4	2012	ALL	Body	Body Control Module (aux.)																																								
4	2012	ALL	Body	Driver Door Switch																																								
4	2012	ALL	Body	HVAC Control Module																																								
4	2012	ALL	Body	Inside Rear View Mirror Module																																								
4	2012	ALL	Body	Instrument Panel Cluster																																								
4	2012	ALL	Body	Left Side Object Detection Module																																								
4	2012	ALL	Body	Lift Gate Module																																								
4	2012	ALL	Body	Memory Seat Module																																								
4	2012	ALL	Body	Park Assist Module																																								
4	2012	ALL	Body	Passenger Door Switch																																								
4	2012	ALL	Body	Passenger Presence System																																								
4	2012	ALL	Body	Radio																																								
4	2012	ALL	Body	Rear Heated Seat Module																																								
4	2012	ALL	Body	Rear HVAC/RSA																																								
4	2012	ALL	Body	Right Side Object Detection Module																																								
4	2012	ALL	Body	Supplemental Inflatable Restraint																																								
4	2012	ALL	Body	Theft Deterrent Module																																								
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
4	2013	ALL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
4	2013	ALL	Chassis	Electronic Brake Control Module																																								
4	2013	ALL	Chassis	Electronic Suspension Control																																								
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																								
4	2013	ALL	Chassis	FPCM with Trailer Brake Control																																								
4	2013	ALL	Body	Amplifier (Bose)																																								
4	2013	ALL	Body	Assist Step Controller																																								
4	2013	ALL	Body	Body Control Module																																								
4	2013	ALL	Body	Body Control Module (aux.)																																								
4	2013	ALL	Body	Driver Door Switch																																								
4	2013	ALL	Body	HVAC Control Module																																								
4	2013	ALL	Body	Inside Rear View Mirror Module																																								
4	2013	ALL	Body	Instrument Panel Cluster																																								
4	2013	ALL	Body	Left Side Object Detection Module																																								
4	2013	ALL	Body	Lift Gate Module																																								
4	2013	ALL	Body	Memory Seat Module																																								
4	2013	ALL	Body	Park Assist Module																																								
4	2013	ALL	Body	Passenger Door Switch																																								
4	2013	ALL	Body	Passenger Presence System																																								
4	2013	ALL	Body	Radio																																								
4	2013	ALL	Body	Rear Heated Seat Module																																								
4	2013	ALL	Body	Rear HVAC/RSA																																								
4	2013	ALL	Body	Right Side Object Detection Module																																								
4	2013	ALL	Body	Supplemental Inflatable Restraint																																								
4	2013	ALL	Body	Theft Deterrent Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
4	2014	Escalade	Powertrain	(F) 6.2L L94 Engine Control Module																																								
4	2014	Escalade	Powertrain	(F) 6.2L L94 Transmission Control Module																																								
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump																																								
4	2014	Escalade	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																								
4	2014	Escalade	Chassis	Electronic Brake Control Module																																								
4	2014	Escalade	Chassis	Suspension Control Module																																								
4	2014	Escalade	Body	Body Control Module																																								
4	2014	Escalade	Body	Auxiliary Body Control Module																																								
4	2014	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
4	2014	Escalade	Body	Passenger Presence Module																																								
4	2014	Escalade	Body	Instrument Cluster																																								
4	2014	Escalade	Body	Radio																																								
4	2014	Escalade	Body	Amplifier																																								
4	2014	Escalade	Body	Rear Audio Control Module																																								
4	2014	Escalade	Body	Digital Radio Receiver Control Module																																								
4	2014	Escalade	Body	Personal Audio Link Control Module																																								
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 9																																								
4	2014	Escalade	Body	Telematics Communication Interface Control Module Version 10																																								
4	2014	Escalade	Body	HVAC Control Module																																								
4	2014	Escalade	Body	Driver Door Switch Panel Control Module																																								
4	2014	Escalade	Body	Passenger Door Switch Panel Control Module																																								
4	2014	Escalade	Body	Liftgate Control Module																																								
4	2014	Escalade	Body	Seat Memory Control Module																																								
4	2014	Escalade	Body	Rear Seat Heating Control Module																																								
4	2014	Escalade	Body	Assist Step Control Module																																								
4	2014	Escalade	Body	Right Side Object Detection Control Module																																								
4	2014	Escalade	Body	Left Side Object Detection Control Module																																								
4	2014	Escalade	Body	Remote Control Door Lock Receiver																																								
4	2014	Escalade	Body	Parking Assist Control Module																																								
4	2014	Escalade	Body	Theft Deterrent Module																																								
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Engine Control Module																																								
4	2014	Escalade ESV	Powertrain	(F) 6.2L L94 Transmission Control Module																																								
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump																																								
4	2014	Escalade ESV	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																								
4	2014	Escalade ESV	Chassis	Electronic Brake Control Module																																								
4	2014	Escalade ESV	Chassis	Suspension Control Module																																								
4	2014	Escalade ESV	Body	Body Control Module																																								
4	2014	Escalade ESV	Body	Auxiliary Body Control Module																																								
4	2014	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
4	2014	Escalade ESV	Body	Passenger Presence Module																																								
4	2014	Escalade ESV	Body	Instrument Cluster																																								
4	2014	Escalade ESV	Body	Radio																																								
4	2014	Escalade ESV	Body	Amplifier																																								
4	2014	Escalade ESV	Body	Rear Audio Control Module																																								
4	2014	Escalade ESV	Body	Digital Radio Receiver Control Module																																								
4	2014	Escalade ESV	Body	Personal Audio Link Control Module																																								
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9																																								
4	2014	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																								
4	2014	Escalade ESV	Body	HVAC Control Module																																								
4	2014	Escalade ESV	Body	Driver Door Switch Panel Control Module																																								
4	2014	Escalade ESV	Body	Passenger Door Switch Panel Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
4	2014	Escalade ESV	Body	Liftgate Control Module																																								
4	2014	Escalade ESV	Body	Seat Memory Control Module																																								
4	2014	Escalade ESV	Body	Rear Seat Heating Control Module																																								
4	2014	Escalade ESV	Body	Assist Step Control Module																																								
4	2014	Escalade ESV	Body	Right Side Object Detection Control Module																																								
4	2014	Escalade ESV	Body	Left Side Object Detection Control Module																																								
4	2014	Escalade ESV	Body	Remote Control Door Lock Receiver																																								
4	2014	Escalade ESV	Body	Parking Assist Control Module																																								
4	2014	Escalade ESV	Body	Theft Deterrent Module																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
4	2015	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
4	2015	Escalade	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control																																								
4	2015	Escalade	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																								
4	2015	Escalade	Powertrain	Transfer Case Version Two Wheel Drive																																								
4	2015	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
4	2015	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
4	2015	Escalade	Powertrain	Drive Motor Control Module 1																																								
4	2015	Escalade	Powertrain	Drive Motor Control Module 2																																								
4	2015	Escalade	Powertrain	Auxiliary Transmission Fluid Pump																																								
4	2015	Escalade	Chassis	Electronic Brake Control Module																																								
4	2015	Escalade	Chassis	Parking Brake Control Module																																								
4	2015	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																								
4	2015	Escalade	Chassis	Power Steering Control Module																																								
4	2015	Escalade	Chassis	Steering Wheel Angle Sensor Module																																								
4	2015	Escalade	Chassis	Suspension Control Module																																								
4	2015	Escalade	Body	Body Control Module																																								
4	2015	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
4	2015	Escalade	Body	Passenger Presence Module																																								
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Left																																								
4	2015	Escalade	Body	Seat Belt Retractor Motor Module - Right																																								
4	2015	Escalade	Body	Instrument Cluster																																								
4	2015	Escalade	Body	Radio/HVAC Control																																								
4	2015	Escalade	Body	Active Safety Control Module																																								
4	2015	Escalade	Body	Video Processing Control Module																																								
4	2015	Escalade	Body	Radio																																								
4	2015	Escalade	Body	Amplifier																																								
4	2015	Escalade	Body	Media Disc Player																																								
4	2015	Escalade	Body	Human Machine Interface Control Module																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.6																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 9.7																																								
4	2015	Escalade	Body	Telematics Communication Interface Control Module Version 10																																								
4	2015	Escalade	Body	HVAC Control Module																																								
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																								
4	2015	Escalade	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																								
4	2015	Escalade	Body	Seat Memory Control Module - Passenger																																								
4	2015	Escalade	Body	Seat Memory Control Module - Driver																																								
4	2015	Escalade	Body	Keyless Entry Control Module																																								
4	2015	Escalade	Body	Assist Step Control Module																																								
4	2015	Escalade	Body	Left Side Object Detection Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
4	2015	Escalade	Body	Parking Assist Control Module																																								
4	2015	Escalade	Body	Frontview Camera Module																																								
4	2015	Escalade	Body	Steering Column Lock Control Module																																								
4	2015	Escalade	Body	Battery Energy Control Module																																								
4	2015	Escalade	Body	Long Range Radar Sensor Module																																								
4	2015	Escalade	Body	Left Front Short Range Radar Sensor Module																																								
4	2015	Escalade	Body	Right Front Short Range Radar Sensor Module																																								
4	2015	Escalade	Body	Left Rear Radar Short Range Sensor Module																																								
4	2015	Escalade	Body	Right Rear Short Range Radar Sensor Module																																								
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																								
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
4	2015	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
4	2015	Escalade ESV	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control																																								
4	2015	Escalade ESV	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																								
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Wheel Drive																																								
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
4	2015	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
4	2015	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
4	2015	Escalade ESV	Chassis	Electronic Brake Control Module																																								
4	2015	Escalade ESV	Chassis	Parking Brake Control Module																																								
4	2015	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																								
4	2015	Escalade ESV	Chassis	Power Steering Control Module																																								
4	2015	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																								
4	2015	Escalade ESV	Chassis	Suspension Control Module																																								
4	2015	Escalade ESV	Body	Body Control Module																																								
4	2015	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
4	2015	Escalade ESV	Body	Passenger Presence Module																																								
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																								
4	2015	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																								
4	2015	Escalade ESV	Body	Instrument Cluster																																								
4	2015	Escalade ESV	Body	Radio/HVAC Control																																								
4	2015	Escalade ESV	Body	Active Safety Control Module																																								
4	2015	Escalade ESV	Body	Video Processing Control Module																																								
4	2015	Escalade ESV	Body	Radio																																								
4	2015	Escalade ESV	Body	Amplifier																																								
4	2015	Escalade ESV	Body	Media Disc Player																																								
4	2015	Escalade ESV	Body	Human Machine Interface Control Module																																								
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.6																																								
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 9.7																																								
4	2015	Escalade ESV	Body	Telematics Communication Interface Control Module Version 10																																								
4	2015	Escalade ESV	Body	HVAC Control Module																																								
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015.5 (AVF)																																								
4	2015	Escalade ESV	Body	Liftgate Control Module Target Implementation MY 2015 (WMF)																																								
4	2015	Escalade ESV	Body	Seat Memory Control Module - Driver																																								
4	2015	Escalade ESV	Body	Keyless Entry Control Module																																								
4	2015	Escalade ESV	Body	Assist Step Control Module																																								
4	2015	Escalade ESV	Body	Left Side Object Detection Control Module																																								
4	2015	Escalade ESV	Body	Parking Assist Control Module																																								
4	2015	Escalade ESV	Body	Frontview Camera Module																																								
4	2015	Escalade ESV	Body	Steering Column Lock Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
4	2015	Escalade ESV	Body	Long Range Radar Sensor Module																																								
4	2015	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																								
4	2015	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																								
4	2015	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																								
4	2015	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																								
4	2016	Escalade	Powertrain	(J) 6.2L L86 Engine Control Module																																								
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
4	2016	Escalade	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
4	2016	Escalade	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
4	2016	Escalade	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
4	2016	Escalade	Chassis	Electronic Brake Control Module																																								
4	2016	Escalade	Chassis	Parking Brake Control Module																																								
4	2016	Escalade	Chassis	Multi-Axis Acceleration Sensor Module																																								
4	2016	Escalade	Chassis	Power Steering Control Module																																								
4	2016	Escalade	Chassis	Steering Wheel Angle Sensor Module																																								
4	2016	Escalade	Chassis	Suspension Control Module																																								
4	2016	Escalade	Body	Body Control Module																																								
4	2016	Escalade	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
4	2016	Escalade	Body	Passenger Presence Module																																								
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Left																																								
4	2016	Escalade	Body	Seat Belt Retractor Motor Module - Right																																								
4	2016	Escalade	Body	Instrument Cluster																																								
4	2016	Escalade	Body	Radio/HVAC Control																																								
4	2016	Escalade	Body	Active Safety Control Module																																								
4	2016	Escalade	Body	Video Processing Control Module																																								
4	2016	Escalade	Body	Radio																																								
4	2016	Escalade	Body	Amplifier																																								
4	2016	Escalade	Body	Media Disc Player																																								
4	2016	Escalade	Body	Human Machine Interface Control Module																																								
4	2016	Escalade	Body	Telematics Communication Interface Control Module																																								
4	2016	Escalade	Body	HVAC Control Module																																								
4	2016	Escalade	Body	Liftgate Control Module																																								
4	2016	Escalade	Body	Seat Memory Control Module - Passenger																																								
4	2016	Escalade	Body	Seat Memory Control Module - Driver																																								
4	2016	Escalade	Body	Keyless Entry Control Module																																								
4	2016	Escalade	Body	Assist Step Control Module																																								
4	2016	Escalade	Body	Left Side Object Detection Control Module																																								
4	2016	Escalade	Body	Parking Assist Control Module																																								
4	2016	Escalade	Body	Frontview Camera Module																																								
4	2016	Escalade	Body	Steering Column Lock Control Module																																								
4	2016	Escalade	Body	Long Range Radar Sensor Module																																								
4	2016	Escalade	Body	Left Front Short Range Radar Sensor Module																																								
4	2016	Escalade	Body	Right Front Short Range Radar Sensor Module																																								
4	2016	Escalade	Body	Left Rear Radar Short Range Sensor Module																																								
4	2016	Escalade	Body	Right Rear Short Range Radar Sensor Module																																								
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Engine Control Module																																								
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
4	2016	Escalade ESV	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
4	2016	Escalade ESV	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
4	2016	Escalade ESV	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
4	2016	Escalade ESV	Chassis	Electronic Brake Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
4	2016	Escalade ESV	Chassis	Parking Brake Control Module																																								
4	2016	Escalade ESV	Chassis	Multi-Axis Acceleration Sensor Module																																								
4	2016	Escalade ESV	Chassis	Power Steering Control Module																																								
4	2016	Escalade ESV	Chassis	Steering Wheel Angle Sensor Module																																								
4	2016	Escalade ESV	Chassis	Suspension Control Module																																								
4	2016	Escalade ESV	Body	Body Control Module																																								
4	2016	Escalade ESV	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
4	2016	Escalade ESV	Body	Passenger Presence Module																																								
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Left																																								
4	2016	Escalade ESV	Body	Seat Belt Retractor Motor Module - Right																																								
4	2016	Escalade ESV	Body	Instrument Cluster																																								
4	2016	Escalade ESV	Body	Radio Control																																								
4	2016	Escalade ESV	Body	HVAC Control																																								
4	2016	Escalade ESV	Body	Active Safety Control Module																																								
4	2016	Escalade ESV	Body	Video Processing Control Module																																								
4	2016	Escalade ESV	Body	Radio																																								
4	2016	Escalade ESV	Body	Amplifier																																								
4	2016	Escalade ESV	Body	Media Disc Player																																								
4	2016	Escalade ESV	Body	Human Machine Interface Control Module																																								
4	2016	Escalade ESV	Body	Telematics Communication Interface Control Module																																								
4	2016	Escalade ESV	Body	HVAC Control Module																																								
4	2016	Escalade ESV	Body	Liftgate Control Module																																								
4	2016	Escalade ESV	Body	Seat Memory Control Module - Passenger																																								
4	2016	Escalade ESV	Body	Seat Memory Control Module - Driver																																								
4	2016	Escalade ESV	Body	Keyless Entry Control Module																																								
4	2016	Escalade ESV	Body	Assist Step Control Module																																								
4	2016	Escalade ESV	Body	Left Side Object Detection Control Module																																								
4	2016	Escalade ESV	Body	Parking Assist Control Module																																								
4	2016	Escalade ESV	Body	Frontview Camera Module																																								
4	2016	Escalade ESV	Body	Steering Column Lock Control Module																																								
4	2016	Escalade ESV	Body	Long Range Radar Sensor Module																																								
4	2016	Escalade ESV	Body	Left Front Short Range Radar Sensor Module																																								
4	2016	Escalade ESV	Body	Right Front Short Range Radar Sensor Module																																								
4	2016	Escalade ESV	Body	Left Rear Radar Short Range Sensor Module																																								
4	2016	Escalade ESV	Body	Right Rear Short Range Radar Sensor Module																																								
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																								
ALL	2004	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																								
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																								
ALL	2004	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																								
ALL	2004	Hearse	Chassis	DRP/ABS/TCS														V	V	V																								
ALL	2004	Hearse	Chassis	Magna Steer																																								
ALL	2004	Hearse	Chassis	Rear Integration Module																																								
ALL	2004	Hearse	Chassis	Tire Pressure Monitor																	V	V																						
ALL	2004	Hearse	Body	Amplifier (Delco)																																								
ALL	2004	Hearse	Body	Dash Integration Module																																								
ALL	2004	Hearse	Body	Driver Door Switch																																								
ALL	2004	Hearse	Body	Driver Door Module																																								
ALL	2004	Hearse	Body	Passenger Door Module																																								
ALL	2004	Hearse	Body	Instrument Panel Cluster																																								
ALL	2004	Hearse	Body	Instrument Panel Module						V																																		
ALL	2004	Hearse	Body	Personalization																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Thefflock LED
ALL	2004	Hearse	Body	Radio																																								
ALL	2004	Hearse	Body	Rear Integration Module																																								
ALL	2004	Hearse	Body	Remote Function Actuation																																								
ALL	2004	Hearse	Body	Supplemental Inflatable Restraint																																								
ALL	2004	Hearse	Body	Vehicle Theft Deterrent																			V																					
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																								
ALL	2004	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																								
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																								
ALL	2004	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																								
ALL	2004	Limousine	Chassis	DRP/ABS/TCS														V	V	V																								
ALL	2004	Limousine	Chassis	Magna Steer																																								
ALL	2004	Limousine	Chassis	Rear Integration Module																																								
ALL	2004	Limousine	Chassis	Tire Pressure Monitor																	V	V																						
ALL	2004	Limousine	Body	Amplifier (Delco)																																								
ALL	2004	Limousine	Body	Dash Integration Module																																								
ALL	2004	Limousine	Body	Driver Door Switch																																								
ALL	2004	Limousine	Body	Driver Door Module																																								
ALL	2004	Limousine	Body	Passenger Door Module																																								
ALL	2004	Limousine	Body	Left Mid Door Module																																								
ALL	2004	Limousine	Body	Left Rear Door Module																																								
ALL	2004	Limousine	Body	Right Mid Door Module																																								
ALL	2004	Limousine	Body	Right Rear Door Module																																								
ALL	2004	Limousine	Body	Instrument Panel Cluster																																								
ALL	2004	Limousine	Body	Instrument Panel Module						V																																		
ALL	2004	Limousine	Body	Memory Seat Module																				V																				
ALL	2004	Limousine	Body	Navigation Radio																																								
ALL	2004	Limousine	Body	Personalization																																								
ALL	2004	Limousine	Body	Radio																																								
ALL	2004	Limousine	Body	Rear Climate Control Panel																																								
ALL	2004	Limousine	Body	Rear Integration Module																																								
ALL	2004	Limousine	Body	Remote Function Actuation																																								
ALL	2004	Limousine	Body	Supplemental Inflatable Restraint																																								
ALL	2004	Limousine	Body	Vehicle Theft Deterrent																			V																					
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																								
ALL	2005	Hearse	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																								
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																								
ALL	2005	Hearse	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																								
ALL	2005	Hearse	Chassis	DRP/ABS/TCS														V	V	V																								
ALL	2005	Hearse	Chassis	Magna Steer																																								
ALL	2005	Hearse	Chassis	Rear Integration Module																																								
ALL	2005	Hearse	Chassis	Tire Pressure Monitor																	V	V																						
ALL	2005	Hearse	Body	Amplifier (Delco)																																								
ALL	2005	Hearse	Body	Dash Integration Module																																								
ALL	2005	Hearse	Body	Driver Door Switch																																								
ALL	2005	Hearse	Body	Driver Door Module																																								
ALL	2005	Hearse	Body	Passenger Door Module																																								
ALL	2005	Hearse	Body	Instrument Panel Cluster																																								
ALL	2005	Hearse	Body	Instrument Panel Module						V																																		
ALL	2005	Hearse	Body	Personalization																																								
ALL	2005	Hearse	Body	Radio																																								
ALL	2005	Hearse	Body	Rear Integration Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
ALL	2005	Hearse	Body	Remote Function Actuation																																								
ALL	2005	Hearse	Body	Supplemental Inflatable Restraint																																								
ALL	2005	Hearse	Body	Vehicle Theft Deterrent																																								
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Engine Control Module																																								
ALL	2005	Limousine	Powertrain	(9) 4.6L V8 L37 Transmission Control Module																																								
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Engine Control Module																																								
ALL	2005	Limousine	Powertrain	(Y) 4.6L V8 LD8 Transmission Control Module																																								
ALL	2005	Limousine	Chassis	DRP/ABS/TCS														V	V	V																								
ALL	2005	Limousine	Chassis	Magna Steer																																								
ALL	2005	Limousine	Chassis	Rear Integration Module																																								
ALL	2005	Limousine	Chassis	Tire Pressure Monitor																	V	V																						
ALL	2005	Limousine	Body	Amplifier (Delco)																																								
ALL	2005	Limousine	Body	Dash Integration Module																																								
ALL	2005	Limousine	Body	Driver Door Switch																																								
ALL	2005	Limousine	Body	Driver Door Module																																								
ALL	2005	Limousine	Body	Passenger Door Module																																								
ALL	2005	Limousine	Body	Left Mid Door Module																																								
ALL	2005	Limousine	Body	Left Rear Door Module																																								
ALL	2005	Limousine	Body	Right Mid Door Module																																								
ALL	2005	Limousine	Body	Right Rear Door Module																																								
ALL	2005	Limousine	Body	Instrument Panel Cluster																																								
ALL	2005	Limousine	Body	Instrument Panel Module						V																																		
ALL	2005	Limousine	Body	Memory Seat Module																				V																				
ALL	2005	Limousine	Body	Navigation Radio																																								
ALL	2005	Limousine	Body	Personalization																																								
ALL	2005	Limousine	Body	Radio																																								
ALL	2005	Limousine	Body	Rear Climate Control Panel																																								
ALL	2005	Limousine	Body	Rear Integration Module																																								
ALL	2005	Limousine	Body	Remote Function Actuation																																								
ALL	2005	Limousine	Body	Supplemental Inflatable Restraint																																								
ALL	2005	Limousine	Body	Vehicle Theft Deterrent																																								
ALL	2006	Hearse	Powertrain	Engine Control Module																					V	V																		
ALL	2006	Hearse	Powertrain	Transmission Control Module																																								
ALL	2006	Hearse	Chassis	Electronic Brake Control Module																																								
ALL	2006	Hearse	Chassis	Air Suspension Control Module																																								
ALL	2006	Hearse	Body	Amplifier (Bose)																																								
ALL	2006	Hearse	Body	Body Control Module																																								
ALL	2006	Hearse	Body	Digital Radio Receiver																																								
ALL	2006	Hearse	Body	Driver Door Switch																																								
ALL	2006	Hearse	Body	Driver Position Module																																								
ALL	2006	Hearse	Body	HVAC Control Module																																								
ALL	2006	Hearse	Body	Inside Rear View Mirror Module																																								
ALL	2006	Hearse	Body	Instrument Panel Cluster																																								
ALL	2006	Hearse	Body	Passenger Door Switch																																								
ALL	2006	Hearse	Body	Passenger Presence System																																								
ALL	2006	Hearse	Body	Radio																																								
ALL	2006	Hearse	Body	Rear Heated Seat Module																																								
ALL	2006	Hearse	Body	Remote Control Door Lock Receiver																																								
ALL	2006	Hearse	Body	Supplemental Inflatable Restraint																																								
ALL	2006	Hearse	Body	Theft Deterrent Module																																								
ALL	2006	Hearse	Body	Vehicle Comm. Interface Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
ALL	2006	Limousine	Powertrain	Engine Control Module																					V	V																		
ALL	2006	Limousine	Powertrain	Transmission Control Module																																								
ALL	2006	Limousine	Chassis	Electronic Brake Control Module																																								
ALL	2006	Limousine	Chassis	Air Suspension Control Module																																								
ALL	2006	Limousine	Body	Amplifier (Bose)																																								
ALL	2006	Limousine	Body	Aux. HVAC Control Module																																								
ALL	2006	Limousine	Body	Body Control Module																																								
ALL	2006	Limousine	Body	Digital Radio Receiver																																								
ALL	2006	Limousine	Body	Driver Door Switch																																								
ALL	2006	Limousine	Body	Driver Position Module																																								
ALL	2006	Limousine	Body	HVAC Control Module																																								
ALL	2006	Limousine	Body	Inside Rear View Mirror Module																																								
ALL	2006	Limousine	Body	Instrument Panel Cluster																																								
ALL	2006	Limousine	Body	Passenger Door Switch																																								
ALL	2006	Limousine	Body	Passenger Presence System																																								
ALL	2006	Limousine	Body	Radio																																								
ALL	2006	Limousine	Body	Rear Heated Seat Module																																								
ALL	2006	Limousine	Body	Remote Control Door Lock Receiver																																								
ALL	2006	Limousine	Body	Supplemental Inflatable Restraint																																								
ALL	2006	Limousine	Body	Theft Deterrent Module																																								
ALL	2006	Limousine	Body	Vehicle Comm. Interface Module																																								
ALL	2007	Hearse	Powertrain	Engine Control Module																																								
ALL	2007	Hearse	Powertrain	Transmission Control Module																																								
ALL	2007	Hearse	Chassis	Air Suspension Control Module																																								
ALL	2007	Hearse	Chassis	Electronic Brake Control Module																																								
ALL	2007	Hearse	Body	Amplifier (Bose)																																								
ALL	2007	Hearse	Body	Body Control Module																																								
ALL	2007	Hearse	Body	Digital Radio Receiver																																								
ALL	2007	Hearse	Body	Driver Door Switch																																								
ALL	2007	Hearse	Body	Driver Position Module																																								
ALL	2007	Hearse	Body	HVAC Control Module																																								
ALL	2007	Hearse	Body	Inside Rear View Mirror Module																																								
ALL	2007	Hearse	Body	Instrument Panel Cluster																																								
ALL	2007	Hearse	Body	Passenger Door Switch																																								
ALL	2007	Hearse	Body	Passenger Presence System																																								
ALL	2007	Hearse	Body	Radio																																								
ALL	2007	Hearse	Body	Rear Heated Seat Module																																								
ALL	2007	Hearse	Body	Supplemental Inflatable Restraint																																								
ALL	2007	Hearse	Body	Theft Deterrent Module																																								
ALL	2007	Limousine	Powertrain	Engine Control Module																																								
ALL	2007	Limousine	Powertrain	Transmission Control Module																																								
ALL	2007	Limousine	Chassis	Air Suspension Control Module																																								
ALL	2007	Limousine	Chassis	Electronic Brake Control Module																																								
ALL	2007	Limousine	Body	Amplifier (Bose)																																								
ALL	2007	Limousine	Body	Aux. HVAC Control Module																																								
ALL	2007	Limousine	Body	Body Control Module																																								
ALL	2007	Limousine	Body	Digital Radio Receiver																																								
ALL	2007	Limousine	Body	Driver Door Switch																																								
ALL	2007	Limousine	Body	Driver Position Module																																								
ALL	2007	Limousine	Body	HVAC Control Module																																								
ALL	2007	Limousine	Body	Inside Rear View Mirror Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
ALL	2007	Limousine	Body	Instrument Panel Cluster																																								
ALL	2007	Limousine	Body	Passenger Door Switch																																								
ALL	2007	Limousine	Body	Passenger Presence System																																								
ALL	2007	Limousine	Body	Radio																																								
ALL	2007	Limousine	Body	Rear Heated Seat Module																																								
ALL	2007	Limousine	Body	Supplemental Inflatable Restraint																																								
ALL	2007	Limousine	Body	Theft Deterrent Module																																								
ALL	2008	Hearse	Powertrain	Engine Control Module																																								
ALL	2008	Hearse	Powertrain	Transmission Control Module																																								
ALL	2008	Hearse	Chassis	Air Suspension Control Module																																								
ALL	2008	Hearse	Chassis	Electronic Brake Control Module																																								
ALL	2008	Hearse	Body	Amplifier (Bose)																																								
ALL	2008	Hearse	Body	Body Control Module																																								
ALL	2008	Hearse	Body	Climate Control Seat Module																																								
ALL	2008	Hearse	Body	Digital Radio Receiver																																								
ALL	2008	Hearse	Body	Driver Door Switch																																								
ALL	2008	Hearse	Body	Driver Position Module																																								
ALL	2008	Hearse	Body	HVAC Control Module																																								
ALL	2008	Hearse	Body	Instrument Panel Cluster																																								
ALL	2008	Hearse	Body	Passenger Door Switch																																								
ALL	2008	Hearse	Body	Passenger Presence System																																								
ALL	2008	Hearse	Body	Radio																																								
ALL	2008	Hearse	Body	Rear Heated Seat Module																																								
ALL	2008	Hearse	Body	Supplemental Inflatable Restraint																																								
ALL	2008	Hearse	Body	Theft Deterrent Module																																								
ALL	2008	Limousine	Powertrain	Engine Control Module																																								
ALL	2008	Limousine	Powertrain	Transmission Control Module																																								
ALL	2008	Limousine	Chassis	Air Suspension Control Module																																								
ALL	2008	Limousine	Chassis	Electronic Brake Control Module																																								
ALL	2008	Limousine	Body	Amplifier (Bose)																																								
ALL	2008	Limousine	Body	Aux. HVAC Control Module																																								
ALL	2008	Limousine	Body	Body Control Module																																								
ALL	2008	Limousine	Body	Climate Control Seat Module																																								
ALL	2008	Limousine	Body	Digital Radio Receiver																																								
ALL	2008	Limousine	Body	Driver Door Switch																																								
ALL	2008	Limousine	Body	Driver Position Module																																								
ALL	2008	Limousine	Body	HVAC Control Module																																								
ALL	2008	Limousine	Body	Instrument Panel Cluster																																								
ALL	2008	Limousine	Body	Passenger Door Switch																																								
ALL	2008	Limousine	Body	Passenger Presence System																																								
ALL	2008	Limousine	Body	Radio																																								
ALL	2008	Limousine	Body	Rear Heated Seat Module																																								
ALL	2008	Limousine	Body	Supplemental Inflatable Restraint																																								
ALL	2008	Limousine	Body	Theft Deterrent Module																																								
ALL	2009	Hearse	Powertrain	Engine Control Module																																								
ALL	2009	Hearse	Powertrain	Transmission Control Module																																								
ALL	2009	Hearse	Chassis	Air Suspension Control Module																																								
ALL	2009	Hearse	Chassis	Electronic Brake Control Module																																								
ALL	2009	Hearse	Body	Amplifier (Bose)																																								
ALL	2009	Hearse	Body	Body Control Module																																								
ALL	2009	Hearse	Body	Climate Control Seat Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
ALL	2009	Hearse	Body	Digital Radio Receiver																																								
ALL	2009	Hearse	Body	Driver Door Switch																																								
ALL	2009	Hearse	Body	Driver Position Module																																								
ALL	2009	Hearse	Body	HVAC Control Module																																								
ALL	2009	Hearse	Body	Instrument Panel Cluster																																								
ALL	2009	Hearse	Body	Passenger Door Switch																																								
ALL	2009	Hearse	Body	Passenger Presence System																																								
ALL	2009	Hearse	Body	Radio																																								
ALL	2009	Hearse	Body	Rear Heated Seat Module																																								
ALL	2009	Hearse	Body	Supplemental Inflatable Restraint																																								
ALL	2009	Hearse	Body	Theft Deterrent Module																																								
ALL	2009	Limousine	Powertrain	Engine Control Module																																								
ALL	2009	Limousine	Powertrain	Transmission Control Module																																								
ALL	2009	Limousine	Chassis	Air Suspension Control Module																																								
ALL	2009	Limousine	Chassis	Electronic Brake Control Module																																								
ALL	2009	Limousine	Body	Amplifier (Bose)																																								
ALL	2009	Limousine	Body	Aux. HVAC Control Module																																								
ALL	2009	Limousine	Body	Body Control Module																																								
ALL	2009	Limousine	Body	Climate Control Seat Module																																								
ALL	2009	Limousine	Body	Digital Radio Receiver																																								
ALL	2009	Limousine	Body	Driver Door Switch																																								
ALL	2009	Limousine	Body	Driver Position Module																																								
ALL	2009	Limousine	Body	HVAC Control Module																																								
ALL	2009	Limousine	Body	Instrument Panel Cluster																																								
ALL	2009	Limousine	Body	Passenger Door Switch																																								
ALL	2009	Limousine	Body	Passenger Presence System																																								
ALL	2009	Limousine	Body	Radio																																								
ALL	2009	Limousine	Body	Rear Heated Seat Module																																								
ALL	2009	Limousine	Body	Supplemental Inflatable Restraint																																								
ALL	2009	Limousine	Body	Theft Deterrent Module																																								
ALL	2010	Hearse	Powertrain	Engine Control Module																																								
ALL	2010	Hearse	Powertrain	Transmission Control Module																																								
ALL	2010	Hearse	Chassis	Air Suspension Control Module																																								
ALL	2010	Hearse	Chassis	Electronic Brake Control Module																																								
ALL	2010	Hearse	Body	Amplifier (Bose)																																								
ALL	2010	Hearse	Body	Body Control Module																																								
ALL	2010	Hearse	Body	Climate Control Seat Module																																								
ALL	2010	Hearse	Body	Digital Radio Receiver																																								
ALL	2010	Hearse	Body	Driver Door Switch																																								
ALL	2010	Hearse	Body	Driver Position Module																																								
ALL	2010	Hearse	Body	HVAC Control Module																																								
ALL	2010	Hearse	Body	Instrument Panel Cluster																																								
ALL	2010	Hearse	Body	Passenger Door Switch																																								
ALL	2010	Hearse	Body	Passenger Presence System																																								
ALL	2010	Hearse	Body	Radio																																								
ALL	2010	Hearse	Body	Rear Heated Seat Module																																								
ALL	2010	Hearse	Body	Supplemental Inflatable Restraint																																								
ALL	2010	Hearse	Body	Theft Deterrent Module																																								
ALL	2010	Hearse	Body	Vehicle Comm. Interface Module																																								
ALL	2010	Limousine	Powertrain	Engine Control Module																																								
ALL	2010	Limousine	Powertrain	Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
ALL	2010	Limousine	Chassis	Air Suspension Control Module																																								
ALL	2010	Limousine	Chassis	Electronic Brake Control Module																																								
ALL	2010	Limousine	Body	Amplifier (Bose)																																								
ALL	2010	Limousine	Body	Aux. HVAC Control Module																																								
ALL	2010	Limousine	Body	Body Control Module																																								
ALL	2010	Limousine	Body	Climate Control Seat Module																																								
ALL	2010	Limousine	Body	Digital Radio Receiver																																								
ALL	2010	Limousine	Body	Driver Door Switch																																								
ALL	2010	Limousine	Body	Driver Position Module																																								
ALL	2010	Limousine	Body	HVAC Control Module																																								
ALL	2010	Limousine	Body	Instrument Panel Cluster																																								
ALL	2010	Limousine	Body	Passenger Door Switch																																								
ALL	2010	Limousine	Body	Passenger Presence System																																								
ALL	2010	Limousine	Body	Radio																																								
ALL	2010	Limousine	Body	Rear Heated Seat Module																																								
ALL	2010	Limousine	Body	Supplemental Inflatable Restraint																																								
ALL	2010	Limousine	Body	Theft Deterrent Module																																								
ALL	2010	Limousine	Body	Vehicle Comm. Interface Module																																								
ALL	2011	Hearse	Powertrain	Engine Control Module																																								
ALL	2011	Hearse	Powertrain	Transmission Control Module																																								
ALL	2011	Hearse	Chassis	Air Suspension Control Module																																								
ALL	2011	Hearse	Chassis	Electronic Brake Control Module																																								
ALL	2011	Hearse	Body	Amplifier (Bose)																																								
ALL	2011	Hearse	Body	Body Control Module																																								
ALL	2011	Hearse	Body	Climate Control Seat Module																																								
ALL	2011	Hearse	Body	Digital Radio Receiver																																								
ALL	2011	Hearse	Body	Driver Door Switch																																								
ALL	2011	Hearse	Body	Driver Position Module																																								
ALL	2011	Hearse	Body	HVAC Control Module																																								
ALL	2011	Hearse	Body	Instrument Panel Cluster																																								
ALL	2011	Hearse	Body	Passenger Door Switch																																								
ALL	2011	Hearse	Body	Passenger Presence System																																								
ALL	2011	Hearse	Body	Radio																																								
ALL	2011	Hearse	Body	Rear Heated Seat Module																																								
ALL	2011	Hearse	Body	Supplemental Inflatable Restraint																																								
ALL	2011	Hearse	Body	Theft Deterrent Module																																								
ALL	2011	Hearse	Body	Vehicle Comm. Interface Module																																								
ALL	2011	Limousine	Powertrain	Engine Control Module																																								
ALL	2011	Limousine	Powertrain	Transmission Control Module																																								
ALL	2011	Limousine	Chassis	Air Suspension Control Module																																								
ALL	2011	Limousine	Chassis	Electronic Brake Control Module																																								
ALL	2011	Limousine	Body	Amplifier (Bose)																																								
ALL	2011	Limousine	Body	Aux. HVAC Control Module																																								
ALL	2011	Limousine	Body	Body Control Module																																								
ALL	2011	Limousine	Body	Climate Control Seat Module																																								
ALL	2011	Limousine	Body	Digital Radio Receiver																																								
ALL	2011	Limousine	Body	Driver Door Switch																																								
ALL	2011	Limousine	Body	Driver Position Module																																								
ALL	2011	Limousine	Body	HVAC Control Module																																								
ALL	2011	Limousine	Body	Instrument Panel Cluster																																								
ALL	2011	Limousine	Body	Passenger Door Switch																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
ALL	2011	Limousine	Body	Passenger Presence System																																								
ALL	2011	Limousine	Body	Radio																																								
ALL	2011	Limousine	Body	Rear Heated Seat Module																																								
ALL	2011	Limousine	Body	Supplemental Inflatable Restraint																																								
ALL	2011	Limousine	Body	Theft Deterrent Module																																								
ALL	2011	Limousine	Body	Vehicle Comm. Interface Module																																								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																			V															
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																			V															
A	2006	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V																									
A	2006	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
A	2006	ALL	Chassis	Power Steering Control Module	V	V																																																					
A	2006	ALL	Body	Body Control Module	V	V																		V	V																																		
A	2006	ALL	Body	Digital Radio Receiver	V	V																																																				
A	2006	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
A	2006	ALL	Body	Radio	V	V																		V	V																																		
A	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
A	2006	ALL	Body	Theft Deterrent Module	V	V																			V																																		
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V															
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module	V	V																		V										V	V																									
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V													V															
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module	V	V																		V										V	V																									
A	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
A	2007	ALL	Chassis	Power Steering Control Module	V	V																																																					
A	2007	ALL	Body	Body Control Module	V	V																		V	V																																		
A	2007	ALL	Body	Digital Radio Receiver	V	V																																																				
A	2007	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
A	2007	ALL	Body	Radio	V	V																		V	V																																		
A	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
A	2007	ALL	Body	Theft Deterrent Module	V	V																			V																																		
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V						V																												
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module	V	V																		V										V	V																									
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V															
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module	V	V																		V										V	V																									
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V													V															
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module	V	V																		V										V	V																									
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
A	2008	HHR	Chassis	Power Steering Control Module	V	V																																																					
A	2008	HHR	Chassis	Power Steering Control Module	V	V																																																					
A	2008	HHR	Body	Body Control Module	V	V																		V	V																																		
A	2008	HHR	Body	Digital Radio Receiver	V	V																																																				
A	2008	HHR	Body	Instrument Panel Cluster	V	V																		V	V																																		
A	2008	HHR	Body	Radio	V	V																		V	V																																		
A	2008	HHR	Body	Supplemental Inflatable Restraint	V	V																			V																																		
A	2008	HHR	Body	Theft Deterrent Module	V	V																			V																																		
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V						V																												
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module	V	V																		V										V	V																									
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V															
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module	V	V																		V										V	V																									
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V													V															
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module	V	V																		V										V	V																									
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
A	2008	HHR Panel	Chassis	Power Steering Control Module	V	V																																																					
A	2008	HHR Panel	Chassis	Power Steering Control Module	V	V																																																					
A	2008	HHR Panel	Body	Body Control Module	V	V																		V	V																																		
A	2008	HHR Panel	Body	Digital Radio Receiver	V	V																																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2008	HHR Panel	Body	Instrument Panel Cluster	V	V																		V	V																																			
A	2008	HHR Panel	Body	Radio	V	V																		V	V																																			
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint	V	V																			V																																			
A	2008	HHR Panel	Body	Theft Deterrent Module	V	V																			V																																			
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module	V	V																		V	V							V																												
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES	V	V																			V																																		
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V																												
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module	V	V																		V											V	V																							
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V												
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module	V	V																		V											V	V																							
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V												
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module	V	V																		V											V	V																							
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
A	2009	HHR	Chassis	Power Steering Control Module	V	V																																																					
A	2009	HHR	Chassis	Power Steering Control Module	V	V																																																					
A	2009	HHR	Body	Body Control Module	V	V																		V	V																																			
A	2009	HHR	Body	Digital Radio Receiver	V	V																		V																																				
A	2009	HHR	Body	Instrument Panel Cluster	V	V																		V	V																																			
A	2009	HHR	Body	Radio	V	V																		V	V																																			
A	2009	HHR	Body	Supplemental Inflatable Restraint	V	V																			V																																			
A	2009	HHR	Body	Theft Deterrent Module	V	V																			V																																			
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V																												
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module	V	V																		V											V	V																							
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V												
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module	V	V																		V											V	V																							
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V												
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module	V	V																		V											V	V																							
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
A	2009	HHR Panel	Chassis	Power Steering Control Module	V	V																																																					
A	2009	HHR Panel	Chassis	Power Steering Control Module	V	V																																																					
A	2009	HHR Panel	Body	Body Control Module	V	V																		V	V																																			
A	2009	HHR Panel	Body	Digital Radio Receiver	V	V																		V																																				
A	2009	HHR Panel	Body	Instrument Panel Cluster	V	V																		V	V																																			
A	2009	HHR Panel	Body	Radio	V	V																		V	V																																			
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint	V	V																			V																																			
A	2009	HHR Panel	Body	Theft Deterrent Module	V	V																			V																																			
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V					V		V																												
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module	V	V																		V											V	V																							
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V												
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module	V	V																		V											V	V																							
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V												
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module	V	V																		V											V	V																							
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
A	2010	HHR	Chassis	Power Steering Control Module	V	V																																																					
A	2010	HHR	Chassis	Power Steering Control Module	V	V																																																					
A	2010	HHR	Body	Body Control Module	V	V																		V	V																																			
A	2010	HHR	Body	Digital Radio Receiver	V	V																		V																																				
A	2010	HHR	Body	Instrument Panel Cluster	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2010	HHR	Body	Radio	V	V																		V	V																																					
A	2010	HHR	Body	Supplemental Inflatable Restraint	V	V																			V																																					
A	2010	HHR	Body	Theft Deterrent Module	V	V																			V																																					
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V					V		V																														
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module	V	V																		V											V	V																									
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V														
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module	V	V																		V											V	V																									
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V														
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module	V	V																		V											V	V																									
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																				
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																				
A	2010	HHR Panel	Chassis	Power Steering Control Module	V	V																																																							
A	2010	HHR Panel	Chassis	Power Steering Control Module	V	V																																																							
A	2010	HHR Panel	Body	Body Control Module	V	V																		V	V																																					
A	2010	HHR Panel	Body	Digital Radio Receiver	V	V																		V																																					
A	2010	HHR Panel	Body	Instrument Panel Cluster	V	V																		V	V																																					
A	2010	HHR Panel	Body	Radio	V	V																		V	V																																					
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint	V	V																			V																																					
A	2010	HHR Panel	Body	Theft Deterrent Module	V	V																			V																																					
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V														
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module	V	V																		V											V	V																									
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V														
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module	V	V																		V											V	V																									
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																				
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																				
A	2011	HHR	Chassis	Power Steering Control Module	V	V																																																							
A	2011	HHR	Body	Body Control Module	V	V																		V	V																																					
A	2011	HHR	Body	Digital Radio Receiver	V	V																		V																																					
A	2011	HHR	Body	Instrument Panel Cluster	V	V																		V	V																																					
A	2011	HHR	Body	Radio	V	V																		V	V																																					
A	2011	HHR	Body	Supplemental Inflatable Restraint	V	V																			V																																					
A	2011	HHR	Body	Theft Deterrent Module	V	V																			V																																					
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V														
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module	V	V																		V											V	V																									
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V														
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module	V	V																		V											V	V																									
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																				
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																				
A	2011	HHR Panel	Chassis	Power Steering Control Module	V	V																																																							
A	2011	HHR Panel	Body	Body Control Module	V	V																		V	V																																					
A	2011	HHR Panel	Body	Digital Radio Receiver	V	V																		V																																					
A	2011	HHR Panel	Body	Instrument Panel Cluster	V	V																		V	V																																					
A	2011	HHR Panel	Body	Radio	V	V																		V	V																																					
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint	V	V																			V																																					
A	2011	HHR Panel	Body	Theft Deterrent Module	V	V																			V																																					
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V																
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V																
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)	V																			V	V				V	V	V	V												V	V																
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)	V																			V	V				V	V	V	V												V	V																
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V																

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)	V																		V	V				V	V	V	V													V	V														
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)	V																		V	V				V	V	V	V													V	V														
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module	V	V																	V	V							V		V																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V														
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V														
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)	V																		V	V				V	V	V	V													V	V														
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)	V																		V	V				V	V	V	V													V	V														
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																	
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																	
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)	V																			V	V																																	
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)	V																			V	V																																	
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V																			V	V																			V	V														
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer	V																			V	V				V	V	V	V														V													
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V																			V	V																			V	V														
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer	V																			V	V				V	V	V	V													V	V														
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer	V																			V	V																			V	V														
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer	V																			V	V				V	V	V	V													V	V														
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer	V																			V	V																				V														
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer	V																			V	V				V	V	V	V													V	V														
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module	V	V																			V																					V													
A	2013	Trax	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V	V						
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
A	2013	Trax	Chassis	Power Steering Control Module	V	V																			V																																	
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
A	2013	Trax	Body	Body Control Module	V	V																		V	V																																	
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
A	2013	Trax	Body	Passenger Presence Module	V	V																			V																																	
A	2013	Trax	Body	Instrument Cluster	V	V																		V	V																																	
A	2013	Trax	Body	Radio	V	V																		V	V																																	
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																	
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																	
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																	
A	2013	Trax	Body	Front Seat Heating Control Module	V	V																		V	V																																	
A	2013	Trax	Body	Parking Assist Control Module	V	V																		V	V																																	
A	2013	Trax	Body	Frontview Camera Module	V	V																		V	V																																	
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V														
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V														
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V														
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V														
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module	V	V																		V	V							V		V																									
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V														
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V														
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																				
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V																			V	V																			V	V														
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer	V																			V	V				V	V	V	V													V														
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V																			V	V																			V	V														
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer	V																			V	V				V	V	V	V												V	V														
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
A	2014	Trax	Powertrain	Fuel Injector Control Module		V																		V	V																																		
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module	V	V																			V																					V												
A	2014	Trax	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
A	2014	Trax	Chassis	Power Steering Control Module	V	V																			V																																		
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
A	2014	Trax	Body	Body Control Module	V	V																		V	V																																		
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
A	2014	Trax	Body	Passenger Presence Module	V	V																			V																																		
A	2014	Trax	Body	Instrument Cluster	V	V																		V	V																																		
A	2014	Trax	Body	Radio	V	V																		V	V																																		
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
A	2014	Trax	Body	Front Seat Heating Control Module	V	V																		V	V																																		
A	2014	Trax	Body	Parking Assist Control Module	V	V																		V	V																																		
A	2014	Trax	Body	Frontview Camera Module	V	V																		V	V																																		
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V														
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V														
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V														
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V														
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V														
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission	V																			V	V																																		
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission	V																			V	V																																		
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																			
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																			
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission	V																			V	V																			V	V														
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission	V																			V	V																			V	V														
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
A	2015	Trax	Powertrain	Fuel Injector Control Module		V																		V	V																																		
A	2015	Trax	Powertrain	Chassis Control Module	V	V																		V	V							V		V																									
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module	V	V																			V																					V												
A	2015	Trax	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
A	2015	Trax	Chassis	Power Steering Control Module	V	V																			V																																		
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
A	2015	Trax	Body	Body Control Module	V	V																		V	V																																		
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
A	2015	Trax	Body	Passenger Presence Module	V	V																			V																																		
A	2015	Trax	Body	Instrument Cluster	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2015	Trax	Body	Radio	V	V																		V	V																																			
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
A	2015	Trax	Body	Seat Memory Control Module	V																																																						
A	2015	Trax	Body	Front Seat Heating Control Module	V	V																		V	V																																		
A	2015	Trax	Body	Right Side Object Detection Control Module	V																			V	V																																		
A	2015	Trax	Body	Left Side Object Detection Control Module	V																			V	V																																		
A	2015	Trax	Body	Parking Assist Control Module	V	V																		V	V																																		
A	2015	Trax	Body	Frontview Camera Module	V	V																		V	V																																		
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																										
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V													V												
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V											
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V											
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V											
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V											
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission	V																			V	V																																		
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission	V																			V	V																																		
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V												
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V											
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
A	2016	Trax	Powertrain	Fuel Injector Control Module		V																		V	V																																		
A	2016	Trax	Powertrain	Chassis Control Module	V	V																		V	V							V		V																								
A	2016	Trax	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
A	2016	Trax	Chassis	Power Steering Control Module	V	V																			V																																	
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
A	2016	Trax	Body	Body Control Module	V	V																		V	V																																	
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
A	2016	Trax	Body	Passenger Presence Module	V	V																			V																																	
A	2016	Trax	Body	Instrument Cluster	V	V																		V	V																																	
A	2016	Trax	Body	Trailer Interface Control Module	V	V																		V	V																																	
A	2016	Trax	Body	Radio	V	V																		V	V																																	
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																	
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																	
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																	
A	2016	Trax	Body	Seat Memory Control Module	V																																																				
A	2016	Trax	Body	Front Seat Heating Control Module	V	V																		V	V																																	
A	2016	Trax	Body	Right Side Object Detection Control Module	V																			V	V																																	
A	2016	Trax	Body	Left Side Object Detection Control Module	V																			V	V																																	
A	2016	Trax	Body	Parking Assist Control Module	V																			V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2016	Trax	Body	Frontview Camera Module	V	V																		V	V																																			
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM	V	V										V	V				V	V		V	V							V														V													
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM		V																		V																																			
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM		V																		V																																			
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM		V																		V																																			
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM	V	V																		V											V	V																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V	V		V	V							V														V													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V											V	V																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V	V		V	V							V														V													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V											V	V																							
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V											V	V																							
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V											V	V																							
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V											V	V																							
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module	V	V										V					V			V								V														V													
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module	V	V																		V											V	V																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module	V	V										V	V				V			V	V							V														V													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600	V	V																		V											V	V																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600	V	V																		V											V	V																							
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V			V	V							V														V													
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V											V	V																							
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module	V	V																		V	V																																		
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module	V	V																		V											V	V	V																						
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V																		V																																			
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V											V	V	V																						
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed	V	V																		V											V	V																							
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed	V	V																		V											V	V	V																						
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW	V	V																		V																																			
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																		
C	2004	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																		
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)		V																		V																																			
C	2004	ALL	Chassis	ESC	V	V																		V	V																																		
C	2004	ALL	Chassis	Rear Wheel Steering	V	V																		V	V																																		
C	2004	ALL	Chassis	Tire Pressure Monitor	V	V																																																				
C	2004	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
C	2004	ALL	Chassis	VSES	V	V																		V	V																																		
C	2004	ALL	Body	Amplifier (Bose)	V	V																			V																																		
C	2004	ALL	Body	Body Control Module	V	V																		V	V																																		
C	2004	ALL	Body	CD Changer	V																																																					
C	2004	ALL	Body	Chime	V	V																		V	V																																		
C	2004	ALL	Body	Driver Door Module	V	V																		V	V																																		
C	2004	ALL	Body	Driver Seat Module	V	V																		V	V																																		
C	2004	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																		
C	2004	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																		
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																		
C	2004	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2004	ALL	Body	OnStar	V	V																		V	V																																			
C	2004	ALL	Body	Passenger Door Module	V	V																		V	V																																			
C	2004	ALL	Body	Passenger Presence System																																																								
C	2004	ALL	Body	Radio Base	V	V																			V																																			
C	2004	ALL	Body	Radio Uplevel	V	V																			V																																			
C	2004	ALL	Body	Radio Navigation	V	V																		V																																			
C	2004	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
C	2004	ALL	Body	Rear HVAC	V	V																			V																																			
C	2004	ALL	Body	Rear Seat Audio	V	V																			V																																			
C	2004	ALL	Body	Rear Seat Entertainment	V																				V																																			
C	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
C	2004	ALL	Body	Vehicle Theft Deterrent	V	V																																																						
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM	V	V										V	V			V	V		V	V							V														V														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM		V																	V																																				
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM		V																	V																																				
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM		V																	V																																				
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM	V	V																	V											V	V																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V			V	V		V	V							V														V														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																	V											V	V																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V			V	V		V	V							V														V														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																	V											V	V																								
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V		V	V							V														V														
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																	V											V	V																								
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V			V	V		V	V							V														V														
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																	V											V	V																								
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module	V	V										V	V			V	V		V	V							V														V														
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module	V	V																	V											V	V																								
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V			V	V		V	V							V														V														
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																	V											V	V																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V			V	V		V	V							V														V														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																	V											V	V																								
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module	V	V										V				V			V								V														V														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module	V	V										V	V			V			V	V							V														V														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600	V	V																	V											V	V																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600	V	V																	V											V	V																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V			V			V	V							V														V														
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																	V											V	V																								
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V																	V																																				
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																	V											V	V	V																							
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module	V	V										V	V			V	V		V	V							V														V														
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed	V	V																	V											V	V																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed	V	V																	V											V	V	V																							
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW	V	V																	V	V																																			
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW	V	V																	V																																				
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																	V	V																																			
C	2005	ALL	Chassis	ABS Over 8600 GVW	V	V																	V	V																																			
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)		V																	V																																				
C	2005	ALL	Chassis	ESC	V	V																	V	V																																			
C	2005	ALL	Chassis	Rear Wheel Steering	V	V																	V	V																																			
C	2005	ALL	Chassis	Tire Pressure Monitor	V	V																																																				
C	2005	ALL	Chassis	Traction Assist (If Equipped)	V	V																	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2005	ALL	Chassis	VSES	V	V																		V	V																																				
C	2005	ALL	Body	Amplifier (Bose)	V	V																			V																																				
C	2005	ALL	Body	Body Control Module	V	V																		V	V																																			
C	2005	ALL	Body	CD Changer	V																																																							
C	2005	ALL	Body	Chime	V	V																		V	V																																			
C	2005	ALL	Body	Disc Player and Video Display	V																				V																																			
C	2005	ALL	Body	Driver Door Module	V	V																		V	V																																			
C	2005	ALL	Body	Driver Seat Module	V	V																		V	V																																			
C	2005	ALL	Body	Generator Battery Control Module	V	V																		V	V																																			
C	2005	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																			
C	2005	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
C	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2005	ALL	Body	Passenger Door Module	V	V																		V	V																																			
C	2005	ALL	Body	Passenger Presence System																																																								
C	2005	ALL	Body	Base Radio	V	V																			V																																			
C	2005	ALL	Body	Uplevel Radio	V	V																			V																																			
C	2005	ALL	Body	Navigation Radio	V	V																		V																																			
C	2005	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
C	2005	ALL	Body	Rear HVAC	V	V																			V																																			
C	2005	ALL	Body	Rear Seat Audio	V	V																			V																																			
C	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
C	2005	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
C	2005	ALL	Body	Vehicle Theft Deterrent	V	V																																																					
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM	V	V										V	V				V	V		V	V							V														V													
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM		V																		V																																			
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM		V																		V																																			
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM		V																		V																																			
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM	V	V																		V										V	V																							
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V	V		V	V							V														V													
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V										V	V																							
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V	V		V	V							V														V													
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V										V	V																							
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V										V	V																							
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module	V	V																		V										V	V																							
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																							
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																							
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module	V	V										V					V			V								V														V													
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module	V	V										V	V				V			V	V							V														V													
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600	V	V																		V										V	V																							
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600	V	V																		V										V	V																							
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V			V	V							V														V													
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V										V	V																							
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module	V	V															V			V																																			
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module	V	V																		V										V	V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display		V																	V	V																																				
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V														V			V																																				
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																	V											V	V	V																							
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display		V																	V	V																																			
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module	V	V										V	V				V	V	V	V							V														V													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed	V	V																	V											V	V	V																							
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed	V	V																	V											V	V																							
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW	V	V																	V	V																																			
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW	V	V																	V																																				
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																	V	V																																			
C	2006	ALL	Chassis	ABS Over 8600 GVW	V	V																	V	V																																			
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)		V																	V																																				
C	2006	ALL	Chassis	ESC	V	V																	V	V																																			
C	2006	ALL	Chassis	Tire Pressure Monitor	V	V																																																					
C	2006	ALL	Chassis	Traction Assist (If Equipped)	V	V																	V																																				
C	2006	ALL	Chassis	VSES	V	V																	V	V																																			
C	2006	ALL	Body	Amplifier (Bose)	V	V																		V																																			
C	2006	ALL	Body	Body Control Module	V	V																	V	V																																			
C	2006	ALL	Body	CD Changer	V																																																					
C	2006	ALL	Body	Chime	V	V																	V	V																																			
C	2006	ALL	Body	Disc Player and Video Display	V																			V																																			
C	2006	ALL	Body	Driver Door Module	V	V																	V	V																																			
C	2006	ALL	Body	Driver Seat Module	V	V																	V	V																																			
C	2006	ALL	Body	Generator Battery Control Module	V	V																	V	V																																			
C	2006	ALL	Body	Heating and Air Conditioning Auto	V	V																	V	V																																			
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																	V	V																																			
C	2006	ALL	Body	Heating and Air Conditioning Manual	V	V																	V	V																																			
C	2006	ALL	Body	Instrument Panel Cluster	V	V																	V	V																																			
C	2006	ALL	Body	Passenger Door Module	V	V																	V	V																																			
C	2006	ALL	Body	Passenger Presence System																																																						
C	2006	ALL	Body	Base Radio	V	V																		V																																			
C	2006	ALL	Body	Uplevel Radio	V	V																		V																																			
C	2006	ALL	Body	Navigation Radio	V	V																	V																																			
C	2006	ALL	Body	Rear Aux. Climate Module	V	V																	V	V																																			
C	2006	ALL	Body	Rear HVAC	V	V																		V																																			
C	2006	ALL	Body	Rear Seat Audio	V	V																		V																																			
C	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
C	2006	ALL	Body	Vehicle Theft Deterrent	V	V																																																					
C	2006	ALL	Body	Vehicle Comm. Interface Module	V	V																	V	V																																			
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V			V	V	V	V																					V													
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																	V											V	V																							
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V	V	V																					V													
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																	V											V	V																							
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V	V	V																					V													
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																	V											V	V																							
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V			V	V	V	V								V													V													
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																	V											V	V																							
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES	V	V																	V	V																																			
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES	V	V																	V	V																																			
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW	V	V																	V	V																																			
C	2007	Avalanche	Chassis	Electronic Suspension Control	V	V																	V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2007	Avalanche	Chassis	Trailer Brake Control Module	V	V																			V																																			
C	2007	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2007	Avalanche	Body	Assist Step Controller	V	V																		V	V																																			
C	2007	Avalanche	Body	Body Control Module	V	V																		V	V																																			
C	2007	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2007	Avalanche	Body	Digital Radio Receiver	V	V																			V																																			
C	2007	Avalanche	Body	Driver Door Switch	V	V																		V	V																																			
C	2007	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2007	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2007	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2007	Avalanche	Body	Memory Seat Module	V	V																		V	V																																			
C	2007	Avalanche	Body	Park Assist Module	V	V																		V	V																																			
C	2007	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																			
C	2007	Avalanche	Body	Passenger Presence System	V	V																			V																																			
C	2007	Avalanche	Body	Radio	V	V																		V	V																																			
C	2007	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																			
C	2007	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2007	Avalanche	Body	Rollover Sensor	V	V																			V																																			
C	2007	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2007	Avalanche	Body	Theft Deterrent Module	V	V																			V																																			
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																								
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V																								
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																								
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V														
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																								
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V																								
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
C	2007	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2007	Suburban	Chassis	Trailer Brake Control Module	V	V																			V																																			
C	2007	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2007	Suburban	Body	Assist Step Controller	V	V																		V	V																																			
C	2007	Suburban	Body	Body Control Module	V	V																		V	V																																			
C	2007	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2007	Suburban	Body	Digital Radio Receiver	V	V																			V																																			
C	2007	Suburban	Body	Driver Door Switch	V	V																		V	V																																			
C	2007	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2007	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2007	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2007	Suburban	Body	Lift Gate Module	V	V																		V	V																																			
C	2007	Suburban	Body	Memory Seat Module	V	V																		V	V																																			
C	2007	Suburban	Body	Park Assist Module	V	V																		V	V																																			
C	2007	Suburban	Body	Passenger Door Switch	V	V																		V	V																																			
C	2007	Suburban	Body	Passenger Presence System	V	V																			V																																			
C	2007	Suburban	Body	Radio	V	V																		V	V																																			
C	2007	Suburban	Body	Rear Heated Seat Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2007	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2007	Suburban	Body	Rollover Sensor	V	V																			V																																			
C	2007	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2007	Suburban	Body	Theft Deterrent Module	V	V																			V																																			
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																								
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																			
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V											V	V																								
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V											V	V																								
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																			
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V											V	V																								
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V																								
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V																								
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V											V	V	V																							
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																			
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V											V	V																								
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V						V			V	V																																			
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																			
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V											V	V	V																							
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
C	2007	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2007	Silverado	Chassis	Trailer Brake Control Module	V	V																			V																																			
C	2007	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2007	Silverado	Body	Body Control Module	V	V																		V	V																																			
C	2007	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2007	Silverado	Body	Digital Radio Receiver	V	V																			V																																			
C	2007	Silverado	Body	Driver Door Switch	V	V																		V	V																																			
C	2007	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2007	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2007	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2007	Silverado	Body	Memory Seat Module	V	V																		V	V																																			
C	2007	Silverado	Body	Park Assist Module	V	V																		V	V																																			
C	2007	Silverado	Body	Passenger Door Switch	V	V																		V	V																																			
C	2007	Silverado	Body	Passenger Presence System	V	V																			V																																			
C	2007	Silverado	Body	Radio	V	V																		V	V																																			
C	2007	Silverado	Body	Rear Heated Seat Module	V	V																			V																																			
C	2007	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2007	Silverado	Body	Rollover Sensor	V	V																			V																																			
C	2007	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2007	Silverado	Body	Theft Deterrent Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V											V	V																							
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V											V	V																							
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V																							
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
C	2007	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2007	Tahoe	Chassis	Trailer Brake Control Module	V	V																			V																																		
C	2007	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2007	Tahoe	Body	Assist Step Controller	V	V																		V	V																																		
C	2007	Tahoe	Body	Body Control Module	V	V																		V	V																																		
C	2007	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2007	Tahoe	Body	Digital Radio Receiver	V	V																			V																																		
C	2007	Tahoe	Body	Driver Door Switch	V	V																		V	V																																		
C	2007	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2007	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2007	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2007	Tahoe	Body	Lift Gate Module	V	V																		V	V																																		
C	2007	Tahoe	Body	Memory Seat Module	V	V																		V	V																																		
C	2007	Tahoe	Body	Park Assist Module	V	V																		V	V																																		
C	2007	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																		
C	2007	Tahoe	Body	Passenger Presence System	V	V																			V																																		
C	2007	Tahoe	Body	Radio	V	V																		V	V																																		
C	2007	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																		
C	2007	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2007	Tahoe	Body	Rollover Sensor	V	V																			V																																		
C	2007	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2007	Tahoe	Body	Theft Deterrent Module	V	V																			V																																		
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V																							
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V																							
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																		
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V											V	V																							
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V													
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																		
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V											V	V																							
C	2008	Avalanche	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2008	Avalanche	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2008	Avalanche	Chassis	Trailer Brake Control Module	V	V																			V																																		
C	2008	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2008	Avalanche	Body	Assist Step Controller	V	V																		V	V																																		
C	2008	Avalanche	Body	Body Control Module	V	V																		V	V																																		
C	2008	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2008	Avalanche	Body	Digital Radio Receiver	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2008	Avalanche	Body	Driver Door Switch	V	V																		V	V																																				
C	2008	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																				
C	2008	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																				
C	2008	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																				
C	2008	Avalanche	Body	Memory Seat Module	V	V																		V	V																																				
C	2008	Avalanche	Body	Park Assist Module	V	V																		V	V																																				
C	2008	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																				
C	2008	Avalanche	Body	Passenger Presence System	V	V																			V																																				
C	2008	Avalanche	Body	Radio	V	V																		V	V																																				
C	2008	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																				
C	2008	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																				
C	2008	Avalanche	Body	Rollover Sensor	V	V																			V																																				
C	2008	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																				
C	2008	Avalanche	Body	Theft Deterrent Module	V	V																			V																																				
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V															
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																				
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V																								
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V															
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																				
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V																								
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V															
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																				
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V											V	V																								
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V															
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V											V	V	V																							
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V															
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																				
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V											V	V																								
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																				
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																				
C	2008	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																				
C	2008	Suburban	Chassis	Trailer Brake Control Module	V	V																			V																																				
C	2008	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																				
C	2008	Suburban	Body	Assist Step Controller	V	V																		V	V																																				
C	2008	Suburban	Body	Body Control Module	V	V																		V	V																																				
C	2008	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																				
C	2008	Suburban	Body	Digital Radio Receiver	V	V																			V																																				
C	2008	Suburban	Body	Driver Door Switch	V	V																		V	V																																				
C	2008	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																				
C	2008	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																				
C	2008	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																				
C	2008	Suburban	Body	Lift Gate Module	V	V																		V	V																																				
C	2008	Suburban	Body	Memory Seat Module	V	V																		V	V																																				
C	2008	Suburban	Body	Park Assist Module	V	V																		V	V																																				
C	2008	Suburban	Body	Passenger Door Switch	V	V																		V	V																																				
C	2008	Suburban	Body	Passenger Presence System	V	V																			V																																				
C	2008	Suburban	Body	Radio	V	V																		V	V																																				
C	2008	Suburban	Body	Rear Heated Seat Module	V	V																			V																																				
C	2008	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																				
C	2008	Suburban	Body	Rollover Sensor	V	V																			V																																				
C	2008	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2008	Suburban	Body	Theft Deterrent Module	V	V																			V																																			
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																		
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																									
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																									
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V																									
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																		
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																									
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V														
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																									
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V														
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																								
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																		
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V																									
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V						V			V	V																																		
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																		
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																		
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																								
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
C	2008	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2008	Silverado	Chassis	Trailer Brake Control Module	V	V																			V																																		
C	2008	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2008	Silverado	Body	Body Control Module	V	V																		V	V																																		
C	2008	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2008	Silverado	Body	Digital Radio Receiver	V	V																			V																																		
C	2008	Silverado	Body	Driver Door Switch	V	V																		V	V																																		
C	2008	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2008	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2008	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2008	Silverado	Body	Memory Seat Module	V	V																		V	V																																		
C	2008	Silverado	Body	Park Assist Module	V	V																		V	V																																		
C	2008	Silverado	Body	Passenger Door Switch	V	V																		V	V																																		
C	2008	Silverado	Body	Passenger Presence System	V	V																			V																																		
C	2008	Silverado	Body	Radio	V	V																		V	V																																		
C	2008	Silverado	Body	Rear Heated Seat Module	V	V																			V																																		
C	2008	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2008	Silverado	Body	Rollover Sensor	V	V																			V																																		
C	2008	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2008	Silverado	Body	Theft Deterrent Module	V	V																			V																																		
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module	V	V																		V	V							V																												
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																		
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																			V															
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																									
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																			V															
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																									
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2008	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2008	Tahoe	Chassis	Trailer Brake Control Module	V	V																			V																																			
C	2008	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2008	Tahoe	Body	Assist Step Controller	V	V																		V	V																																			
C	2008	Tahoe	Body	Body Control Module	V	V																		V	V																																			
C	2008	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2008	Tahoe	Body	Digital Radio Receiver	V	V																			V																																			
C	2008	Tahoe	Body	Driver Door Switch	V	V																		V	V																																			
C	2008	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2008	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2008	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2008	Tahoe	Body	Memory Seat Module	V	V																		V	V																																			
C	2008	Tahoe	Body	Park Assist Module	V	V																		V	V																																			
C	2008	Tahoe	Body	Passenger Presence System	V	V																			V																																			
C	2008	Tahoe	Body	Radio	V	V																		V	V																																			
C	2008	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																			
C	2008	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2008	Tahoe	Body	Rollover Sensor	V	V																			V																																			
C	2008	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2008	Tahoe	Body	Theft Deterrent Module	V	V																			V																																			
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V						V													V															
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																				
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																				
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module	V	V																																																					
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module	V	V																			V																																			
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Body	Body Control Module	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver	V	V																			V																																			
C	2008	Tahoe Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Body	Memory Seat Module	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Body	Park Assist Module	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Body	Passenger Presence System	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2008	Tahoe Hybrid	Body	Radio	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Body	Rollover Sensor	V	V																			V																																			
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V														
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed	V	V																		V										V	V																									
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V														
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed	V	V																		V										V	V																									
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V														
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed	V	V																		V										V	V																									
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V													V														
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Avalanche	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2009	Avalanche	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2009	Avalanche	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
C	2009	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2009	Avalanche	Body	Assist Step Controller	V	V																		V	V																																			
C	2009	Avalanche	Body	Body Control Module	V	V																		V	V																																			
C	2009	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2009	Avalanche	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2009	Avalanche	Body	Driver Door Switch	V	V																		V	V																																			
C	2009	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2009	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2009	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2009	Avalanche	Body	Memory Seat Module	V	V																		V	V																																			
C	2009	Avalanche	Body	Park Assist Module	V	V																		V	V																																			
C	2009	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																			
C	2009	Avalanche	Body	Passenger Presence System	V	V																			V																																			
C	2009	Avalanche	Body	Radio	V	V																		V	V																																			
C	2009	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																			
C	2009	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2009	Avalanche	Body	Rollover Sensor	V	V																			V																																			
C	2009	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2009	Avalanche	Body	Theft Deterrent Module	V	V																			V																																			
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																									
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V																									
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V														
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V														
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Right Front Solenoid Valves	ABS Left Front Solenoid Valves	ABS Right Rear Solenoid Valves	ABS Left Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																				
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																				
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES	V	V																		V	V																																				
C	2009	Cheyenne	Chassis	Trailer Brake Control Module	V	V																		V	V																																				
C	2009	Cheyenne	Body	Amplifier (Bose)	V	V																		V	V																																				
C	2009	Cheyenne	Body	Body Control Module (aux.)	V	V																		V	V																																				
C	2009	Cheyenne	Body	Digital Radio Receiver	V	V																		V	V																																				
C	2009	Cheyenne	Body	Driver Door Switch	V	V																		V	V																																				
C	2009	Cheyenne	Body	Instrument Panel Cluster	V	V																		V	V																																				
C	2009	Cheyenne	Body	Park Assist Module	V	V																		V	V																																				
C	2009	Cheyenne	Body	Passenger Door Switch	V	V																		V	V																																				
C	2009	Cheyenne	Body	Passenger Presence System	V	V																			V																																				
C	2009	Cheyenne	Body	Rear Heated Seat Module	V	V																			V																																				
C	2009	Cheyenne	Body	Rear HVAC/RSA	V	V																		V	V																																				
C	2009	Cheyenne	Body	Rollover Sensor	V	V																			V																																				
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint	V	V																			V																																				
C	2009	Cheyenne	Body	Theft Deterrent Module	V	V																			V																																				
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V															
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																				
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																				
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																								
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																				
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V	V																								
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																								
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																				
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V	V																								
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																				
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																								
C	2009	Suburban	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																				
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																				
C	2009	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																				
C	2009	Suburban	Chassis	Trailer Brake Control Module	V	V																		V	V																																				
C	2009	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																				
C	2009	Suburban	Body	Assist Step Controller	V	V																		V	V																																				
C	2009	Suburban	Body	Body Control Module	V	V																		V	V																																				
C	2009	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																				
C	2009	Suburban	Body	Digital Radio Receiver	V	V																		V	V																																				
C	2009	Suburban	Body	Driver Door Switch	V	V																		V	V																																				
C	2009	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																				
C	2009	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																				
C	2009	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																				
C	2009	Suburban	Body	Left Side Object Detection Module	V	V																		V	V																																				
C	2009	Suburban	Body	Lift Gate Module	V	V																		V	V																																				
C	2009	Suburban	Body	Memory Seat Module	V	V																		V	V																																				
C	2009	Suburban	Body	Park Assist Module	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Right Front Solenoid Valves	ABS Left Front Solenoid Valves	ABS Right Rear Solenoid Valves	ABS Left Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2009	Suburban	Body	Passenger Door Switch	V	V																		V	V																																			
C	2009	Suburban	Body	Passenger Presence System	V	V																			V																																			
C	2009	Suburban	Body	Radio	V	V																		V	V																																			
C	2009	Suburban	Body	Rear Heated Seat Module	V	V																			V																																			
C	2009	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2009	Suburban	Body	Right Side Object Detection Module	V	V																			V																																			
C	2009	Suburban	Body	Rollover Sensor	V	V																			V																																			
C	2009	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2009	Suburban	Body	Theft Deterrent Module	V	V																			V																																			
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V		V	V			V	V						V														V														
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																									
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed	V	V																		V										V	V																									
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed	V	V																		V										V	V																									
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V														V														
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V	V	V		V				V			V	V	V	V		V	V		V	V						V														V														
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V														V														
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																			
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																			
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES	V	V																		V	V																																			
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																			
C	2009	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2009	Silverado	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
C	2009	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2009	Silverado	Body	Body Control Module	V	V																		V	V																																			
C	2009	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2009	Silverado	Body	Digital Radio Receiver	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2009	Silverado	Body	Driver Door Switch	V	V																		V	V																																			
C	2009	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2009	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2009	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2009	Silverado	Body	Memory Seat Module	V	V																		V	V																																			
C	2009	Silverado	Body	Park Assist Module	V	V																		V	V																																			
C	2009	Silverado	Body	Passenger Door Switch	V	V																		V	V																																			
C	2009	Silverado	Body	Passenger Presence System	V	V																			V																																			
C	2009	Silverado	Body	Radio	V	V																		V	V																																			
C	2009	Silverado	Body	Rear Heated Seat Module	V	V																			V																																			
C	2009	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2009	Silverado	Body	Rollover Sensor	V	V																			V																																			
C	2009	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2009	Silverado	Body	Theft Deterrent Module	V	V																			V																																			
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V													
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																					
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																					
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module	V	V																																																					
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
C	2009	Silverado Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	Body Control Module	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	Digital Radio Receiver	V	V																			V																																			
C	2009	Silverado Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	Memory Seat Module	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	Park Assist Module	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	Passenger Presence System	V	V																			V																																			
C	2009	Silverado Hybrid	Body	Radio	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	Rollover Sensor	V	V																			V																																			
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2009	Silverado Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																									
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V		V	V			V	V							V													V														
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																								
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V	V																								
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																									
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																								
C	2009	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2009	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2009	Tahoe	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
C	2009	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2009	Tahoe	Body	Assist Step Controller	V	V																		V	V																																			
C	2009	Tahoe	Body	Body Control Module	V	V																		V	V																																			
C	2009	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2009	Tahoe	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2009	Tahoe	Body	Driver Door Switch	V	V																		V	V																																			
C	2009	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2009	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2009	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2009	Tahoe	Body	Left Side Object Detection Module	V	V																		V	V																																			
C	2009	Tahoe	Body	Lift Gate Module	V	V																		V	V																																			
C	2009	Tahoe	Body	Memory Seat Module	V	V																		V	V																																			
C	2009	Tahoe	Body	Park Assist Module	V	V																		V	V																																			
C	2009	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																			
C	2009	Tahoe	Body	Passenger Presence System	V	V																			V																																			
C	2009	Tahoe	Body	Radio	V	V																		V	V																																			
C	2009	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																			
C	2009	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2009	Tahoe	Body	Right Side Object Detection Module	V	V																			V																																			
C	2009	Tahoe	Body	Rollover Sensor	V	V																			V																																			
C	2009	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2009	Tahoe	Body	Theft Deterrent Module	V	V																			V																																			
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																				
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																				
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module	V	V																																																					
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module	V	V																			V																																			
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Body	Body Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver	V	V																			V																																			
C	2009	Tahoe Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Body	Heated Seat Module	V	V																			V																																			
C	2009	Tahoe Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Body	Park Assist Module	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Body	Passenger Presence System	V	V																			V																																			
C	2009	Tahoe Hybrid	Body	Radio	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module	V	V																			V																																			
C	2009	Tahoe Hybrid	Body	Rollover Sensor	V	V																			V																																			
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																						
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																						
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Avalanche	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2010	Avalanche	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2010	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2010	Avalanche	Body	Assist Step Controller	V	V																		V	V																																			
C	2010	Avalanche	Body	Body Control Module	V	V																		V	V																																			
C	2010	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2010	Avalanche	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2010	Avalanche	Body	Driver Door Switch	V	V																		V	V																																			
C	2010	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2010	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2010	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2010	Avalanche	Body	Memory Seat Module	V	V																		V	V																																			
C	2010	Avalanche	Body	Park Assist Module	V	V																			V																																			
C	2010	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																			
C	2010	Avalanche	Body	Passenger Presence System	V	V																			V																																			
C	2010	Avalanche	Body	Radio	V	V																		V	V																																			
C	2010	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																			
C	2010	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2010	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2010	Avalanche	Body	Theft Deterrent Module	V	V																			V																																			
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																						
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V	V																						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES	V	V																		V	V																																			
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																			
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES	V	V																		V	V																																			
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2010	Cheyenne	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2010	Cheyenne	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2010	Cheyenne	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2010	Cheyenne	Body	Driver Door Switch	V	V																		V	V																																			
C	2010	Cheyenne	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2010	Cheyenne	Body	Park Assist Module	V	V																			V																																			
C	2010	Cheyenne	Body	Passenger Door Switch	V	V																		V	V																																			
C	2010	Cheyenne	Body	Passenger Presence System	V	V																			V																																			
C	2010	Cheyenne	Body	Rear Heated Seat Module	V	V																			V																																			
C	2010	Cheyenne	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2010	Cheyenne	Body	Theft Deterrent Module	V	V																			V																																			
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																				V															
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																							
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V	V																							
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																							
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																							
C	2010	Suburban	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																			
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
C	2010	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2010	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2010	Suburban	Body	Assist Step Controller	V	V																		V	V																																			
C	2010	Suburban	Body	Body Control Module	V	V																		V	V																																			
C	2010	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2010	Suburban	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2010	Suburban	Body	Driver Door Switch	V	V																		V	V																																			
C	2010	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2010	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2010	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2010	Suburban	Body	Left Side Object Detection Module	V	V																		V	V																																			
C	2010	Suburban	Body	Lift Gate Module	V	V																		V	V																																			
C	2010	Suburban	Body	Memory Seat Module	V	V																		V	V																																			
C	2010	Suburban	Body	Park Assist Module	V	V																			V																																			
C	2010	Suburban	Body	Passenger Door Switch	V	V																		V	V																																			
C	2010	Suburban	Body	Passenger Presence System	V	V																			V																																			
C	2010	Suburban	Body	Radio	V	V																		V	V																																			
C	2010	Suburban	Body	Rear Heated Seat Module	V	V																			V																																			
C	2010	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2010	Suburban	Body	Right Side Object Detection Module	V	V																			V																																			
C	2010	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2010	Suburban	Body	Theft Deterrent Module	V	V																			V																																			
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																									
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																								
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																								
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V													V														
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V													V														
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																								
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																								
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																			
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																			
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																								
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES	V	V																		V	V																																			
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																			
C	2010	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																			
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																			
C	2010	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2010	Silverado	Body	Body Control Module	V	V																		V	V																																			
C	2010	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2010	Silverado	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2010	Silverado	Body	Driver Door Switch	V	V																		V	V																																			
C	2010	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2010	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2010	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2010	Silverado	Body	Memory Seat Module	V	V																		V	V																																			
C	2010	Silverado	Body	Park Assist Module	V	V																			V																																			
C	2010	Silverado	Body	Passenger Door Switch	V	V																		V	V																																			
C	2010	Silverado	Body	Passenger Presence System	V	V																			V																																			
C	2010	Silverado	Body	Radio	V	V																		V	V																																			
C	2010	Silverado	Body	Rear Heated Seat Module	V	V																			V																																			
C	2010	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2010	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2010	Silverado	Body	Theft Deterrent Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																		
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																					
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																					
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module	V	V																																																				
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		
C	2010	Silverado Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2010	Silverado Hybrid	Body	Body Control Module	V	V																		V	V																																		
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2010	Silverado Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2010	Silverado Hybrid	Body	Driver Door Switch	V	V																		V	V																																		
C	2010	Silverado Hybrid	Body	Heated Seat Module	V	V																			V																																		
C	2010	Silverado Hybrid	Body	HVAC Control Module	V	V																		V	V																																		
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2010	Silverado Hybrid	Body	Park Assist Module	V	V																			V																																		
C	2010	Silverado Hybrid	Body	Passenger Door Switch	V	V																		V	V																																		
C	2010	Silverado Hybrid	Body	Passenger Presence System	V	V																			V																																		
C	2010	Silverado Hybrid	Body	Radio	V	V																		V	V																																		
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module	V	V																			V																																		
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																		
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2010	Silverado Hybrid	Body	Theft Deterrent Module	V	V																			V																																		
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V														
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																						
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																			V														
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																						
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
C	2010	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2010	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2010	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2010	Tahoe	Body	Assist Step Controller	V	V																		V	V																																		
C	2010	Tahoe	Body	Body Control Module	V	V																		V	V																																		
C	2010	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2010	Tahoe	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2010	Tahoe	Body	Driver Door Switch	V	V																		V	V																																		
C	2010	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2010	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2010	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2010	Tahoe	Body	Left Side Object Detection Module	V	V																		V	V																																		
C	2010	Tahoe	Body	Lift Gate Module	V	V																		V	V																																		
C	2010	Tahoe	Body	Memory Seat Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2010	Tahoe	Body	Park Assist Module	V	V																			V																																			
C	2010	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																			
C	2010	Tahoe	Body	Passenger Presence System	V	V																			V																																			
C	2010	Tahoe	Body	Radio	V	V																		V	V																																			
C	2010	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																			
C	2010	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2010	Tahoe	Body	Right Side Object Detection Module	V	V																			V																																			
C	2010	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2010	Tahoe	Body	Theft Deterrent Module	V	V																			V																																			
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V													
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																					
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																					
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module	V	V																																																					
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Body Control Module	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Heated Seat Module	V	V																			V																																			
C	2010	Tahoe Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Lift Gate Module	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Park Assist Module	V	V																			V																																			
C	2010	Tahoe Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Passenger Presence System	V	V																			V																																			
C	2010	Tahoe Hybrid	Body	Radio	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module	V	V																			V																																			
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2011	Avalanche	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2011	Avalanche	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2011	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																					
C	2011	Avalanche	Body	Assist Step Controller	V	V																		V	V																																					
C	2011	Avalanche	Body	Body Control Module	V	V																		V	V																																					
C	2011	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																					
C	2011	Avalanche	Body	Digital Radio Receiver	V	V																		V	V																																					
C	2011	Avalanche	Body	Driver Door Switch	V	V																		V	V																																					
C	2011	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																					
C	2011	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																					
C	2011	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																					
C	2011	Avalanche	Body	Memory Seat Module	V	V																		V	V																																					
C	2011	Avalanche	Body	Park Assist Module	V	V																			V																																					
C	2011	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																					
C	2011	Avalanche	Body	Passenger Presence System	V	V																			V																																					
C	2011	Avalanche	Body	Radio	V	V																		V	V																																					
C	2011	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																					
C	2011	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																					
C	2011	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																					
C	2011	Avalanche	Body	Theft Deterrent Module	V	V																			V																																					
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																															
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V														V																
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																					
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission	V																			V	V			V			V																														
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission	V																			V	V			V			V														V																
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																					
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																													
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V													V																
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module	V	V																		V	V							V		V																											
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																					
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																													
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V													V																
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																					
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V								V	V	V	V		V															
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V								V	V	V	V	V	V															
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module	V	V																		V	V							V		V																											
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																					
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																				
C	2011	Captiva	Chassis	Electronic Brake Control Module	V	V																		V	V																												V						V
C	2011	Captiva	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
C	2011	Captiva	Body	Body Control Module	V	V																		V	V																																					
C	2011	Captiva	Body	Auxiliary Body Control Module	V	V																		V	V																																					
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																					
C	2011	Captiva	Body	Instrument Cluster	V	V																		V	V																																					
C	2011	Captiva	Body	Headlamp Control Module	V	V																		V	V																																					
C	2011	Captiva	Body	HVAC Control Module	V																			V	V																																					
C	2011	Captiva	Body	Remote Control Door Lock Receiver	V	V																		V	V																																					
C	2011	Captiva	Body	Parking Assist Control Module	V	V																		V	V																																					
C	2011	Captiva	Body	Theft Deterrent Module	V	V																			V																																					
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V																
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V	V																									
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																					
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V																

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES	V	V																		V	V																																		
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																		
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES	V	V																		V	V																																		
C	2011	Cheyenne	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2011	Cheyenne	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2011	Cheyenne	Body	Body Control Module	V	V																		V	V																																		
C	2011	Cheyenne	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2011	Cheyenne	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2011	Cheyenne	Body	Driver Door Switch	V	V																		V	V																																		
C	2011	Cheyenne	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2011	Cheyenne	Body	Park Assist Module	V	V																			V																																		
C	2011	Cheyenne	Body	Passenger Door Switch	V	V																		V	V																																		
C	2011	Cheyenne	Body	Passenger Presence System	V	V																			V																																		
C	2011	Cheyenne	Body	Rear Heated Seat Module	V	V																			V																																		
C	2011	Cheyenne	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2011	Cheyenne	Body	Theft Deterrent Module	V	V																			V																																		
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V		V	V			V	V																			V														
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V														
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
C	2011	Suburban	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																		
C	2011	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2011	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2011	Suburban	Body	Assist Step Controller	V	V																		V	V																																		
C	2011	Suburban	Body	Body Control Module	V	V																		V	V																																		
C	2011	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2011	Suburban	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2011	Suburban	Body	Driver Door Switch	V	V																		V	V																																		
C	2011	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2011	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2011	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2011	Suburban	Body	Left Side Object Detection Module	V	V																		V	V																																		
C	2011	Suburban	Body	Lift Gate Module	V	V																		V	V																																		
C	2011	Suburban	Body	Memory Seat Module	V	V																		V	V																																		
C	2011	Suburban	Body	Park Assist Module	V	V																			V																																		
C	2011	Suburban	Body	Passenger Door Switch	V	V																		V	V																																		
C	2011	Suburban	Body	Passenger Presence System	V	V																			V																																		
C	2011	Suburban	Body	Radio	V	V																		V	V																																		
C	2011	Suburban	Body	Rear Heated Seat Module	V	V																			V																																		
C	2011	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2011	Suburban	Body	Right Side Object Detection Module	V	V																			V																																					
C	2011	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																					
C	2011	Suburban	Body	Theft Deterrent Module	V	V																			V																																					
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V	V	V						V			V	V	V	V		V	V		V	V							V													V																
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V							V													V																
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																											
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V																
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																					
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																											
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V																
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																					
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																										
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V																
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																					
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																										
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic	V	V			V				V		V	V	V	V	V		V	V		V	V							V													V																
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V																
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																										
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V																
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																					
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																										
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V								V						V			V	V																																					
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module		V													V					V	V																																					
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module	V	V																		V	V																																					
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module	V	V																		V										V	V	V																										
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																					
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																					
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module	V	V																		V	V																																					
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																										
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																					
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																					
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES	V	V																		V	V																																					
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																					
C	2011	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																					
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																					
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																					
C	2011	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																					
C	2011	Silverado	Body	Body Control Module	V	V																		V	V																																					
C	2011	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																					
C	2011	Silverado	Body	Digital Radio Receiver	V	V																		V	V																																					
C	2011	Silverado	Body	Driver Door Switch	V	V																		V	V																																					
C	2011	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																					
C	2011	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																					
C	2011	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																					
C	2011	Silverado	Body	Memory Seat Module	V	V																		V	V																																					
C	2011	Silverado	Body	Park Assist Module	V	V																			V																																					
C	2011	Silverado	Body	Passenger Door Switch	V	V																		V	V																																					
C	2011	Silverado	Body	Passenger Presence System	V	V																			V																																					
C	2011	Silverado	Body	Radio	V	V																		V	V																																					
C	2011	Silverado	Body	Rear Heated Seat Module	V	V																			V																																					
C	2011	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2011	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2011	Silverado	Body	Theft Deterrent Module	V	V																			V																																			
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																		
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																					
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																					
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module	V	V																																																					
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		
C	2011	Silverado Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2011	Silverado Hybrid	Body	Body Control Module	V	V																		V	V																																		
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2011	Silverado Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2011	Silverado Hybrid	Body	Driver Door Switch	V	V																		V	V																																		
C	2011	Silverado Hybrid	Body	Heated Seat Module	V	V																			V																																		
C	2011	Silverado Hybrid	Body	HVAC Control Module	V	V																		V	V																																		
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2011	Silverado Hybrid	Body	Park Assist Module	V	V																			V																																		
C	2011	Silverado Hybrid	Body	Passenger Door Switch	V	V																		V	V																																		
C	2011	Silverado Hybrid	Body	Passenger Presence System	V	V																			V																																		
C	2011	Silverado Hybrid	Body	Radio	V	V																		V	V																																		
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module	V	V																			V																																		
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																		
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2011	Silverado Hybrid	Body	Theft Deterrent Module	V	V																			V																																		
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																			V														
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																						
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
C	2011	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2011	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2011	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2011	Tahoe	Body	Assist Step Controller	V	V																		V	V																																		
C	2011	Tahoe	Body	Body Control Module	V	V																		V	V																																		
C	2011	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2011	Tahoe	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2011	Tahoe	Body	Driver Door Switch	V	V																		V	V																																		
C	2011	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2011	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2011	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2011	Tahoe	Body	Left Side Object Detection Module	V	V																		V	V																																		
C	2011	Tahoe	Body	Lift Gate Module	V	V																		V	V																																		
C	2011	Tahoe	Body	Memory Seat Module	V	V																		V	V																																		
C	2011	Tahoe	Body	Park Assist Module	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2011	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																			
C	2011	Tahoe	Body	Passenger Presence System	V	V																			V																																			
C	2011	Tahoe	Body	Radio	V	V																		V	V																																			
C	2011	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																			
C	2011	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2011	Tahoe	Body	Right Side Object Detection Module	V	V																			V																																			
C	2011	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2011	Tahoe	Body	Theft Deterrent Module	V	V																			V																																			
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																					
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																					
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module	V	V																																																					
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Body Control Module	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Heated Seat Module	V	V																			V																																			
C	2011	Tahoe Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Lift Gate Module	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Park Assist Module	V	V																			V																																			
C	2011	Tahoe Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Passenger Presence System	V	V																			V																																			
C	2011	Tahoe Hybrid	Body	Radio	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module	V	V																			V																																			
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2012	Avalanche	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2012	Avalanche	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2012	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																				
C	2012	Avalanche	Body	Assist Step Controller	V	V																		V	V																																				
C	2012	Avalanche	Body	Body Control Module	V	V																		V	V																																				
C	2012	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																				
C	2012	Avalanche	Body	Digital Radio Receiver	V	V																		V	V																																				
C	2012	Avalanche	Body	Driver Door Switch	V	V																		V	V																																				
C	2012	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																				
C	2012	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																				
C	2012	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																				
C	2012	Avalanche	Body	Memory Seat Module	V	V																		V	V																																				
C	2012	Avalanche	Body	Navigation Radio	V	V																		V	V																																				
C	2012	Avalanche	Body	Park Assist Module	V	V																			V																																				
C	2012	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																				
C	2012	Avalanche	Body	Passenger Presence System	V	V																			V																																				
C	2012	Avalanche	Body	Radio	V	V																		V	V																																				
C	2012	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																				
C	2012	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																				
C	2012	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																				
C	2012	Avalanche	Body	Theft Deterrent Module	V	V																			V																																				
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																														
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V														V															
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission	V																			V	V			V			V																													
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission	V																			V	V			V			V														V															
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																											
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V															
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module	V	V																		V	V							V		V																										
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																											
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V															
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module	V	V																		V	V							V		V																										
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V									V	V	V	V		V													
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V									V	V	V	V	V	V													
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V									V	V	V	V		V													
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V									V	V	V	V	V	V													
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module	V	V																		V	V							V		V																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																				
C	2012	Captiva	Chassis	Electronic Brake Control Module	V	V																		V	V																												V						V
C	2012	Captiva	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
C	2012	Captiva	Body	Body Control Module	V	V																		V	V																																				
C	2012	Captiva	Body	Auxiliary Body Control Module	V	V																		V	V																																				
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																				
C	2012	Captiva	Body	Instrument Cluster	V	V																		V	V																																				
C	2012	Captiva	Body	Headlamp Control Module	V	V																		V	V																																				
C	2012	Captiva	Body	HVAC Control Module	V																			V	V																																				
C	2012	Captiva	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
C	2012	Captiva	Body	Parking Assist Control Module	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2012	Captiva	Body	Theft Deterrent Module	V	V																			V																																			
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V	V																						
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																						
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																		
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES	V	V																		V	V																																		
C	2012	Cheyenne	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2012	Cheyenne	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2012	Cheyenne	Body	Body Control Module	V	V																		V	V																																		
C	2012	Cheyenne	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2012	Cheyenne	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2012	Cheyenne	Body	Driver Door Switch	V	V																		V	V																																		
C	2012	Cheyenne	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2012	Cheyenne	Body	Park Assist Module	V	V																			V																																		
C	2012	Cheyenne	Body	Passenger Door Switch	V	V																		V	V																																		
C	2012	Cheyenne	Body	Passenger Presence System	V	V																			V																																		
C	2012	Cheyenne	Body	Rear Heated Seat Module	V	V																			V																																		
C	2012	Cheyenne	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2012	Cheyenne	Body	Theft Deterrent Module	V	V																			V																																		
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V	V																						
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																			V													
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																						
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																						
C	2012	Suburban	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																		
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
C	2012	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2012	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2012	Suburban	Body	Assist Step Controller	V	V																		V	V																																		
C	2012	Suburban	Body	Body Control Module	V	V																		V	V																																		
C	2012	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2012	Suburban	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2012	Suburban	Body	Driver Door Switch	V	V																		V	V																																		
C	2012	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2012	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2012	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2012	Suburban	Body	Left Side Object Detection Module	V	V																		V	V																																			
C	2012	Suburban	Body	Lift Gate Module	V	V																		V	V																																			
C	2012	Suburban	Body	Memory Seat Module	V	V																		V	V																																			
C	2012	Suburban	Body	Navigation Radio	V	V																		V	V																																			
C	2012	Suburban	Body	Park Assist Module	V	V																			V																																			
C	2012	Suburban	Body	Passenger Door Switch	V	V																		V	V																																			
C	2012	Suburban	Body	Passenger Presence System	V	V																			V																																			
C	2012	Suburban	Body	Radio	V	V																		V	V																																			
C	2012	Suburban	Body	Rear Heated Seat Module	V	V																			V																																			
C	2012	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2012	Suburban	Body	Right Side Object Detection Module	V	V																			V																																			
C	2012	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2012	Suburban	Body	Theft Deterrent Module	V	V																			V																																			
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																			
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																									
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																								
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic	V	V			V				V		V	V	V	V	V		V	V		V	V						V														V														
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																								
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																								
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V								V						V			V	V																																			
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module		V													V					V	V																																			
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module	V	V																		V	V																																			
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module	V	V																		V										V	V	V																								
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																			
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																			
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module	V	V																		V	V																																			
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																								
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES	V	V																		V	V																																			
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																			
C	2012	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																			
C	2012	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2012	Silverado	Body	Body Control Module	V	V																		V	V																																			
C	2012	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2012	Silverado	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2012	Silverado	Body	Driver Door Switch	V	V																		V	V																																			
C	2012	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2012	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																				
C	2012	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																				
C	2012	Silverado	Body	Memory Seat Module	V	V																		V	V																																				
C	2012	Silverado	Body	Navigation Radio	V	V																		V	V																																				
C	2012	Silverado	Body	Park Assist Module	V	V																			V																																				
C	2012	Silverado	Body	Passenger Door Switch	V	V																		V	V																																				
C	2012	Silverado	Body	Passenger Presence System	V	V																			V																																				
C	2012	Silverado	Body	Radio	V	V																		V	V																																				
C	2012	Silverado	Body	Rear Heated Seat Module	V	V																			V																																				
C	2012	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																				
C	2012	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																				
C	2012	Silverado	Body	Theft Deterrent Module	V	V																			V																																				
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V														
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																				
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																				
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																				
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																				
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																						
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																					
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V											V		V																								
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																				
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module	V	V																																																						
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module	V	V																			V																																				
C	2012	Silverado Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	Body Control Module	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	Driver Door Switch	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	Heated Seat Module	V	V																			V																																				
C	2012	Silverado Hybrid	Body	HVAC Control Module	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	Navigation Radio	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	Park Assist Module	V	V																			V																																				
C	2012	Silverado Hybrid	Body	Passenger Door Switch	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	Passenger Presence System	V	V																			V																																				
C	2012	Silverado Hybrid	Body	Radio	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module	V	V																			V																																				
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																				
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																				
C	2012	Silverado Hybrid	Body	Theft Deterrent Module	V	V																			V																																				
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																				V															
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																				
C	2012	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
C	2012	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																				
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																				
C	2012	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																				
C	2012	Tahoe	Body	Assist Step Controller	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2012	Tahoe	Body	Body Control Module	V	V																		V	V																																			
C	2012	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2012	Tahoe	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2012	Tahoe	Body	Driver Door Switch	V	V																		V	V																																			
C	2012	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2012	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2012	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2012	Tahoe	Body	Left Side Object Detection Module	V	V																		V	V																																			
C	2012	Tahoe	Body	Lift Gate Module	V	V																		V	V																																			
C	2012	Tahoe	Body	Memory Seat Module	V	V																		V	V																																			
C	2012	Tahoe	Body	Navigation Radio	V	V																		V	V																																			
C	2012	Tahoe	Body	Park Assist Module	V	V																			V																																			
C	2012	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																			
C	2012	Tahoe	Body	Passenger Presence System	V	V																			V																																			
C	2012	Tahoe	Body	Radio	V	V																		V	V																																			
C	2012	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																			
C	2012	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2012	Tahoe	Body	Right Side Object Detection Module	V	V																			V																																			
C	2012	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2012	Tahoe	Body	Theft Deterrent Module	V	V																			V																																			
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V														
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																				
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																				
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module	V	V																																																					
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Body Control Module	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Heated Seat Module	V	V																			V																																			
C	2012	Tahoe Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Lift Gate Module	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Navigation Radio	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Park Assist Module	V	V																			V																																			
C	2012	Tahoe Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Passenger Presence System	V	V																			V																																			
C	2012	Tahoe Hybrid	Body	Radio	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																				
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V														
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V														
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
C	2013	Avalanche	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2013	Avalanche	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2013	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2013	Avalanche	Body	Assist Step Controller	V	V																		V	V																																		
C	2013	Avalanche	Body	Body Control Module	V	V																		V	V																																		
C	2013	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2013	Avalanche	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2013	Avalanche	Body	Driver Door Switch	V	V																		V	V																																		
C	2013	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2013	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2013	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2013	Avalanche	Body	Memory Seat Module	V	V																		V	V																																		
C	2013	Avalanche	Body	Navigation Radio	V	V																		V	V																																		
C	2013	Avalanche	Body	Park Assist Module	V	V																			V																																		
C	2013	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																		
C	2013	Avalanche	Body	Passenger Presence System	V	V																			V																																		
C	2013	Avalanche	Body	Radio	V	V																		V	V																																		
C	2013	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																		
C	2013	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2013	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2013	Avalanche	Body	Theft Deterrent Module	V	V																			V																																		
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																												
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V														V													
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission	V																			V	V			V			V																												
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission	V																			V	V			V			V														V													
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																										
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V													V													
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																										
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V													V													
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module	V	V																		V	V							V		V																									
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V													
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V								V	V	V	V	V	V													
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																	
C	2013	Captiva	Chassis	Electronic Brake Control Module	V	V																		V	V																												V						V
C	2013	Captiva	Chassis	Parking Brake Control Module	V	V																			V																													V	V	V	V		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto	V	V																		V	V																																					
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual	V	V																		V	V																																					
C	2013	Captiva	Body	Auxiliary Body Control Module	V	V																		V	V																																					
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																					
C	2013	Captiva	Body	Instrument Cluster	V	V																		V	V																																					
C	2013	Captiva	Body	Headlamp Control Module	V	V																		V	V																																					
C	2013	Captiva	Body	HVAC Control Module	V																			V	V																																					
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)	V	V																		V	V																																					
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)	V	V																		V	V																																					
C	2013	Captiva	Body	Theft Deterrent Module	V	V																			V																																					
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V	V	V						V			V	V	V	V		V	V		V	V						V														V																
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V						V														V																
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																										
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V																
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																									
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																					
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V																
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																									
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																					
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																					
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																					
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																					
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES	V	V																		V	V																																					
C	2013	Cheyenne	Chassis	Electronic Suspension Control	V	V																		V	V																																					
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																					
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																					
C	2013	Cheyenne	Body	Amplifier (Bose)	V	V																		V	V																																					
C	2013	Cheyenne	Body	Body Control Module	V	V																		V	V																																					
C	2013	Cheyenne	Body	Body Control Module (aux.)	V	V																		V	V																																					
C	2013	Cheyenne	Body	Digital Radio Receiver	V	V																		V	V																																					
C	2013	Cheyenne	Body	Driver Door Switch	V	V																		V	V																																					
C	2013	Cheyenne	Body	Instrument Panel Cluster	V	V																		V	V																																					
C	2013	Cheyenne	Body	Park Assist Module	V	V																			V																																					
C	2013	Cheyenne	Body	Passenger Door Switch	V	V																		V	V																																					
C	2013	Cheyenne	Body	Passenger Presence System	V	V																			V																																					
C	2013	Cheyenne	Body	Rear Heated Seat Module	V	V																			V																																					
C	2013	Cheyenne	Body	Rear HVAC/RSA	V	V																		V	V																																					
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint	V	V																			V																																					
C	2013	Cheyenne	Body	Theft Deterrent Module	V	V																			V																																					
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V																
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																									
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																					
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																				V																
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																									
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																					
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V																
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																									
C	2013	Suburban	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																					
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																					
C	2013	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																					
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2013	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2013	Suburban	Body	Assist Step Controller	V	V																		V	V																																			
C	2013	Suburban	Body	Body Control Module	V	V																		V	V																																			
C	2013	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2013	Suburban	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2013	Suburban	Body	Driver Door Switch	V	V																		V	V																																			
C	2013	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2013	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2013	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2013	Suburban	Body	Left Side Object Detection Module	V	V																		V	V																																			
C	2013	Suburban	Body	Lift Gate Module	V	V																		V	V																																			
C	2013	Suburban	Body	Memory Seat Module	V	V																		V	V																																			
C	2013	Suburban	Body	Navigation Radio	V	V																		V	V																																			
C	2013	Suburban	Body	Park Assist Module	V	V																			V																																			
C	2013	Suburban	Body	Passenger Door Switch	V	V																		V	V																																			
C	2013	Suburban	Body	Passenger Presence System	V	V																			V																																			
C	2013	Suburban	Body	Radio	V	V																		V	V																																			
C	2013	Suburban	Body	Rear Heated Seat Module	V	V																			V																																			
C	2013	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2013	Suburban	Body	Right Side Object Detection Module	V	V																			V																																			
C	2013	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2013	Suburban	Body	Theft Deterrent Module	V	V																			V																																			
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V	V	V						V			V	V	V		V	V			V	V						V														V														
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V	V	V						V			V	V	V		V	V			V	V						V														V														
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																			
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																									
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic	V	V			V				V		V	V	V	V	V		V	V		V	V						V														V														
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V			V				V		V	V	V	V	V		V	V		V	V						V														V														
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module	V																				V																																			
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																							
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V								V						V			V	V																																			
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module		V													V					V	V																																			
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module	V	V																		V	V																																			
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module	V	V																		V										V	V	V																							
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																			
C	2013	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																			
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																			
C	2013	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2013	Silverado	Body	Body Control Module	V	V																		V	V																																			
C	2013	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2013	Silverado	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2013	Silverado	Body	Driver Door Switch	V	V																		V	V																																			
C	2013	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2013	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2013	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2013	Silverado	Body	Memory Seat Module	V	V																		V	V																																			
C	2013	Silverado	Body	Navigation Radio	V	V																		V	V																																			
C	2013	Silverado	Body	Park Assist Module	V	V																			V																																			
C	2013	Silverado	Body	Passenger Door Switch	V	V																		V	V																																			
C	2013	Silverado	Body	Passenger Presence System	V	V																			V																																			
C	2013	Silverado	Body	Radio	V	V																		V	V																																			
C	2013	Silverado	Body	Rear Heated Seat Module	V	V																			V																																			
C	2013	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2013	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2013	Silverado	Body	Theft Deterrent Module	V	V																			V																																			
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V															
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																				
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																				
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V											V		V																							
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module	V	V																																																					
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
C	2013	Silverado Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2013	Silverado Hybrid	Body	Body Control Module	V	V																		V	V																																			
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2013	Silverado Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2013	Silverado Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
C	2013	Silverado Hybrid	Body	Heated Seat Module	V	V																			V																																			
C	2013	Silverado Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2013	Silverado Hybrid	Body	Navigation Radio	V	V																		V	V																																			
C	2013	Silverado Hybrid	Body	Park Assist Module	V	V																			V																																			
C	2013	Silverado Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
C	2013	Silverado Hybrid	Body	Passenger Presence System	V	V																			V																																			
C	2013	Silverado Hybrid	Body	Radio	V	V																		V	V																																			
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																				
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2013	Silverado Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																				V														
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
C	2013	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2013	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2013	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2013	Tahoe	Body	Assist Step Controller	V	V																		V	V																																		
C	2013	Tahoe	Body	Body Control Module	V	V																		V	V																																		
C	2013	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2013	Tahoe	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2013	Tahoe	Body	Driver Door Switch	V	V																		V	V																																		
C	2013	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2013	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2013	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2013	Tahoe	Body	Left Side Object Detection Module	V	V																		V	V																																		
C	2013	Tahoe	Body	Lift Gate Module	V	V																		V	V																																		
C	2013	Tahoe	Body	Memory Seat Module	V	V																		V	V																																		
C	2013	Tahoe	Body	Navigation Radio	V	V																		V	V																																		
C	2013	Tahoe	Body	Park Assist Module	V	V																			V																																		
C	2013	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																		
C	2013	Tahoe	Body	Passenger Presence System	V	V																			V																																		
C	2013	Tahoe	Body	Radio	V	V																		V	V																																		
C	2013	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																		
C	2013	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2013	Tahoe	Body	Right Side Object Detection Module	V	V																			V																																		
C	2013	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2013	Tahoe	Body	Theft Deterrent Module	V	V																			V																																		
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																		
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																		
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																		
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																		
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																				
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																				
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module	V	V																																																				
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2013	Tahoe Hybrid	Body	Body Control Module	V	V																		V	V																																		
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2013	Tahoe Hybrid	Body	Driver Door Switch	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2013	Tahoe Hybrid	Body	Heated Seat Module	V	V																			V																																			
C	2013	Tahoe Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
C	2013	Tahoe Hybrid	Body	Lift Gate Module	V	V																		V	V																																			
C	2013	Tahoe Hybrid	Body	Navigation Radio	V	V																		V	V																																			
C	2013	Tahoe Hybrid	Body	Park Assist Module	V	V																			V																																			
C	2013	Tahoe Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
C	2013	Tahoe Hybrid	Body	Passenger Presence System	V	V																			V																																			
C	2013	Tahoe Hybrid	Body	Radio	V	V																		V	V																																			
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module	V	V																			V																																			
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module	V																			V	V	V	V	V	V	V	V	V																												
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																			
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module	V	V																		V	V																												V						
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
C	2014	Captiva (3GN)	Body	Body Control Module	V	V																		V	V																																			
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2014	Captiva (3GN)	Body	Passenger Presence Module	V	V																			V																																			
C	2014	Captiva (3GN)	Body	Instrument Cluster	V	V														V				V	V																																			
C	2014	Captiva (3GN)	Body	Radio	V	V																		V	V																																			
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module		V																			V																																			
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
C	2014	Captiva (3GN)	Body	HVAC Control Module	V	V																		V	V																																			
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module	V	V																			V																																			
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
C	2014	Captiva (3GN)	Body	Parking Assist Control Module	V	V																		V	V																																			
C	2014	Captiva (3GN)	Body	Theft Deterrent Module	V	V																			V																																			
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V		V																													
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V		V														V														
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission	V																			V	V			V		V																													
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission	V																			V	V			V		V														V														
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																											
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V														
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																											
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V														
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V														
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V								V	V	V	V	V	V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
C	2014	Captiva (Other)	Powertrain	Chassis Control Module	V	V																		V	V							V		V																											
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																				
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module	V	V																		V	V																												V						V
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto	V	V																		V	V																																		
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual	V	V																		V	V																																		
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module	V	V																		V	V																																		
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
C	2014	Captiva (Other)	Body	Instrument Cluster	V	V																		V	V																																		
C	2014	Captiva (Other)	Body	Headlamp Control Module	V	V																		V	V																																		
C	2014	Captiva (Other)	Body	HVAC Control Module	V																			V	V																																		
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)	V	V																		V	V																																		
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)	V	V																		V	V																																		
C	2014	Captiva (Other)	Body	Theft Deterrent Module	V	V																			V																																		
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V				V	V	V	V	V													V														
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V				V	V	V	V	V													V														
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V														
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V														
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V													V														
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V									V														
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V														
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V										V	V	V	V									V														
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																		
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																		
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																		
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
C	2014	Cheyenne	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
C	2014	Cheyenne	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
C	2014	Cheyenne	Chassis	Power Steering Control Module	V	V																		V	V																																		
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
C	2014	Cheyenne	Body	Body Control Module	V	V																		V	V																																		
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
C	2014	Cheyenne	Body	Passenger Presence Module	V	V																			V																																		
C	2014	Cheyenne	Body	Instrument Cluster	V	V																		V	V																																		
C	2014	Cheyenne	Body	Radio Control	V																				V																																		
C	2014	Cheyenne	Body	HVAC Control	V																			V	V																																		
C	2014	Cheyenne	Body	Radio	V	V																		V	V																																		
C	2014	Cheyenne	Body	Amplifier	V	V																			V																																		
C	2014	Cheyenne	Body	Media Disc Player	V	V																		V	V																																		
C	2014	Cheyenne	Body	Human Machine Interface Control Module	V	V																		V	V																					V														
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
C	2014	Cheyenne	Body	HVAC Control Module	V	V																		V	V																																		
C	2014	Cheyenne	Body	Left Side Object Detection Control Module	V	V																		V	V																																		
C	2014	Cheyenne	Body	Parking Assist Control Module	V																			V	V																																		
C	2014	Cheyenne	Body	Frontview Camera Module	V	V																		V	V																																		
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V				V	V	V	V	V													V														
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V				V	V	V	V	V													V														
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V										V	V	V	V									V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V														
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V														
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V										V	V	V	V									V														
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module	V	V																		V	V										V	V	V	V		V																				
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																			
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																			
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																			
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
C	2014	Silverado	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
C	2014	Silverado	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
C	2014	Silverado	Chassis	Power Steering Control Module	V	V																		V	V																																			
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2014	Silverado	Body	Body Control Module	V	V																		V	V																																			
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2014	Silverado	Body	Passenger Presence Module	V	V																			V																																			
C	2014	Silverado	Body	Instrument Cluster	V	V																		V	V																																			
C	2014	Silverado	Body	Radio Control	V																				V																																			
C	2014	Silverado	Body	HVAC Control	V																			V	V																																			
C	2014	Silverado	Body	Radio	V	V																		V	V																																			
C	2014	Silverado	Body	Amplifier	V	V																			V																																			
C	2014	Silverado	Body	Media Disc Player	V	V																		V	V																																			
C	2014	Silverado	Body	Human Machine Interface Control Module	V	V																		V	V																						V													
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																			
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
C	2014	Silverado	Body	Parking Assist Control Module	V																			V	V																																			
C	2014	Silverado	Body	Frontview Camera Module	V	V																		V	V																																			
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module	V	V																		V	V										V	V	V	V									V														
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V													V														
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V									V														
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V													V														
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module	V	V																		V																																			
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V										V	V	V	V									V														
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module	V																			V	V						V		V																											
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module		V								V					V					V	V																																			
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module	V	V																		V	V										V	V	V	V		V																				
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																			
C	2014	Silverado HD	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
C	2014	Silverado HD	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
C	2014	Silverado HD	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
C	2014	Silverado HD	Chassis	Suspension Control Module	V	V																		V	V																																			
C	2014	Silverado HD	Body	Body Control Module	V	V																		V	V																																			
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
C	2014	Silverado HD	Body	Passenger Presence Module	V	V																			V																																			
C	2014	Silverado HD	Body	Instrument Cluster	V	V																		V	V																																			
C	2014	Silverado HD	Body	Chime Alarm Control Module	V																			V	V																																			
C	2014	Silverado HD	Body	Base Radio	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2014	Silverado HD	Body	Navigation Radio	V	V																		V	V																																				
C	2014	Silverado HD	Body	Uplevel Radio	V	V																		V	V																																				
C	2014	Silverado HD	Body	Amplifier	V	V																			V																																				
C	2014	Silverado HD	Body	Rear Audio Control Module	V	V																			V																																				
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module	V	V																		V	V																																				
C	2014	Silverado HD	Body	Personal Audio Link Control Module	V																				V																																				
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																				
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																				
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																				
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																				
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)	V	V																		V	V																																				
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																				
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module	V	V																		V	V																							V												
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																				
C	2014	Silverado HD	Body	Seat Memory Control Module	V	V																		V	V																																				
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
C	2014	Silverado HD	Body	Parking Assist Control Module	V	V																		V	V																																				
C	2014	Silverado HD	Body	Theft Deterrent Module	V	V																			V																																				
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module	V																			V	V	V			V	V	V	V	V													V														
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module	V																			V	V	V			V	V	V	V	V													V													
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module	V	V																		V	V										V	V	V	V									V													
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V																												
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control	V	V									V									V	V							V																												
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																			
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
C	2014	Suburban	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						V
C	2014	Suburban	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
C	2014	Suburban	Chassis	Suspension Control Module	V	V																		V	V																																			
C	2014	Suburban	Body	Body Control Module	V	V																		V	V																																			
C	2014	Suburban	Body	Auxiliary Body Control Module	V	V																		V	V																																			
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
C	2014	Suburban	Body	Passenger Presence Module	V	V																			V																																			
C	2014	Suburban	Body	Instrument Cluster	V	V																		V	V																																			
C	2014	Suburban	Body	Base Radio	V	V																		V	V																																			
C	2014	Suburban	Body	Navigation Radio	V	V																		V	V																																			
C	2014	Suburban	Body	Uplevel Radio	V	V																		V	V																																			
C	2014	Suburban	Body	Amplifier	V	V																			V																																			
C	2014	Suburban	Body	Rear Audio Control Module	V	V																			V																																			
C	2014	Suburban	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
C	2014	Suburban	Body	Personal Audio Link Control Module	V																				V																																			
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)	V	V																		V	V																																			
C	2014	Suburban	Body	Driver Door Switch Panel Control Module	V	V																		V	V																							V												
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																			
C	2014	Suburban	Body	Liftgate Control Module	V	V																			V																						V												
C	2014	Suburban	Body	Seat Memory Control Module	V	V																		V	V																																			
C	2014	Suburban	Body	Rear Seat Heating Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2014	Suburban	Body	Assist Step Control Module	V	V																		V	V																																			
C	2014	Suburban	Body	Right Side Object Detection Control Module	V	V																		V	V																																			
C	2014	Suburban	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
C	2014	Suburban	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
C	2014	Suburban	Body	Parking Assist Control Module	V	V																		V	V																																			
C	2014	Suburban	Body	Theft Deterrent Module	V	V																			V																																			
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module	V																			V	V	V			V	V	V	V	V													V													
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module	V	V																		V	V										V	V	V	V									V												
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V																											
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control	V	V									V									V	V							V																											
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
C	2014	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						V
C	2014	Tahoe	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V			
C	2014	Tahoe	Chassis	Suspension Control Module	V	V																		V	V																																			
C	2014	Tahoe	Body	Body Control Module	V	V																		V	V																																			
C	2014	Tahoe	Body	Auxiliary Body Control Module	V	V																		V	V																																			
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
C	2014	Tahoe	Body	Passenger Presence Module	V	V																			V																																			
C	2014	Tahoe	Body	Instrument Cluster	V	V																		V	V																																			
C	2014	Tahoe	Body	Base Radio	V	V																		V	V																																			
C	2014	Tahoe	Body	Navigation Radio	V	V																		V	V																																			
C	2014	Tahoe	Body	Uplevel Radio	V	V																		V	V																																			
C	2014	Tahoe	Body	Amplifier	V	V																			V																																			
C	2014	Tahoe	Body	Rear Audio Control Module	V	V																			V																																			
C	2014	Tahoe	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
C	2014	Tahoe	Body	Personal Audio Link Control Module	V																				V																																			
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)	V	V																		V	V																																			
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V												
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																			
C	2014	Tahoe	Body	Liftgate Control Module	V	V																			V																						V												
C	2014	Tahoe	Body	Seat Memory Control Module	V	V																		V	V																																			
C	2014	Tahoe	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
C	2014	Tahoe	Body	Assist Step Control Module	V	V																		V	V																																			
C	2014	Tahoe	Body	Right Side Object Detection Control Module	V	V																		V	V																																			
C	2014	Tahoe	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
C	2014	Tahoe	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
C	2014	Tahoe	Body	Parking Assist Control Module	V	V																		V	V																																			
C	2014	Tahoe	Body	Theft Deterrent Module	V	V																			V																																			
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																													
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V													V															
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V														
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V							V	V	V	V	V	V														
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																			
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module	V	V																		V	V																												V						
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module	V	V																			V																						V								V	V	V	V			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2015	Captiva (3GN)	Body	Body Control Module	V	V																		V	V																																					
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																				
C	2015	Captiva (3GN)	Body	Passenger Presence Module	V	V																			V																																				
C	2015	Captiva (3GN)	Body	Instrument Cluster	V	V														V				V	V																																			
C	2015	Captiva (3GN)	Body	Radio	V	V																		V	V																																			
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module		V																			V																																			
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
C	2015	Captiva (3GN)	Body	HVAC Control Module	V	V																		V	V																																			
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module	V	V																			V																																			
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
C	2015	Captiva (3GN)	Body	Parking Assist Control Module	V	V																		V	V																																			
C	2015	Captiva (3GN)	Body	Theft Deterrent Module	V	V																			V																																			
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																													
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V														V														
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission	V																			V	V			V			V																												
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission	V																			V	V			V			V													V														
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																											
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V														
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V														
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V								V	V	V	V	V	V														
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
C	2015	Captiva (Other)	Powertrain	Chassis Control Module	V	V																		V	V							V		V																									
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																			
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module	V	V																		V	V																												V						V
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto	V	V																		V	V																																			
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual	V	V																		V	V																																			
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module	V	V																		V	V																																			
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2015	Captiva (Other)	Body	Instrument Cluster	V	V																		V	V																																			
C	2015	Captiva (Other)	Body	Headlamp Control Module	V	V																		V	V																																			
C	2015	Captiva (Other)	Body	HVAC Control Module	V																			V	V																																			
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)	V	V																		V	V																																			
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)	V	V																		V	V																																			
C	2015	Captiva (Other)	Body	Theft Deterrent Module	V	V																			V																																			
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V				V	V	V	V	V												V														
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V				V	V	V	V	V												V														
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V												V														
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V												V														
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module	V	V																		V																																			
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V														
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																			
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																				
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																			
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)	V	V																		V	V																																			
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
C	2015	Cheyenne	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V							
C	2015	Cheyenne	Chassis	Power Steering Control Module	V	V																		V	V																																			
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2015	Cheyenne	Chassis	Suspension Control Module	V	V																		V	V																																			
C	2015	Cheyenne	Body	Body Control Module	V	V																		V	V																																			
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2015	Cheyenne	Body	Passenger Presence Module	V	V																			V																																			
C	2015	Cheyenne	Body	Instrument Cluster	V	V																		V	V																																			
C	2015	Cheyenne	Body	Radio Controls	V																				V																																			
C	2015	Cheyenne	Body	HVAC Controls	V																			V	V																																			
C	2015	Cheyenne	Body	Radio	V	V																		V	V																																			
C	2015	Cheyenne	Body	Amplifier	V	V																			V																																			
C	2015	Cheyenne	Body	Media Disc Player	V	V																		V	V																																			
C	2015	Cheyenne	Body	Human Machine Interface Control Module	V	V																		V	V																								V											
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
C	2015	Cheyenne	Body	HVAC Control Module	V	V																		V	V																																			
C	2015	Cheyenne	Body	Parking Assist Control Module	V																			V	V																																			
C	2015	Cheyenne	Body	Frontview Camera Module	V	V																		V	V																																			
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module	V	V																		V																																			
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V										V	V	V	V									V													
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V										V	V	V	V		V																			
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module	V																			V	V						V		V																											
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module		V								V					V					V	V																																			
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)	V	V																		V	V										V	V	V	V		V																			
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)	V	V																		V	V										V	V	V	V		V																			
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																			
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																			
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																			
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																			
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																			
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)	V	V																		V	V																																			
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
C	2015	Silverado	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V							
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
C	2015	Silverado	Chassis	Power Steering Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2015	Silverado	Chassis	Suspension Control Module	V	V																		V	V																																			
C	2015	Silverado	Body	Body Control Module	V	V																		V	V																																			
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2015	Silverado	Body	Passenger Presence Module	V	V																			V																																			
C	2015	Silverado	Body	Instrument Cluster	V	V																		V	V																																			
C	2015	Silverado	Body	Radio Controls	V																				V																																			
C	2015	Silverado	Body	HVAC Controls	V																			V	V																																			
C	2015	Silverado	Body	Radio	V	V																		V	V																																			
C	2015	Silverado	Body	Amplifier	V	V																			V																																			
C	2015	Silverado	Body	Media Disc Player	V	V																		V	V																																			
C	2015	Silverado	Body	Human Machine Interface Control Module	V	V																		V	V																								V											
C	2015	Silverado	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																			
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
C	2015	Silverado	Body	Parking Assist Control Module	V																			V	V																																			
C	2015	Silverado	Body	Frontview Camera Module	V	V																		V	V																																			
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V													
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V													
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																			
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																			
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control	V	V																		V	V																																			
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																			
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
C	2015	Suburban	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V	V						
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
C	2015	Suburban	Chassis	Parking Brake Control Module	V	V																			V																						V						V	V	V	V		
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
C	2015	Suburban	Chassis	Power Steering Control Module	V	V																		V	V																																			
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2015	Suburban	Chassis	Suspension Control Module	V	V																		V	V																																			
C	2015	Suburban	Body	Body Control Module	V	V																		V	V																																			
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2015	Suburban	Body	Passenger Presence Module	V	V																			V																																			
C	2015	Suburban	Body	Instrument Cluster	V	V																		V	V																																			
C	2015	Suburban	Body	Radio Controls	V																				V																																			
C	2015	Suburban	Body	HVAC Controls	V																			V	V																																			
C	2015	Suburban	Body	Radio	V	V																		V	V																																			
C	2015	Suburban	Body	Amplifier	V	V																			V																																			
C	2015	Suburban	Body	Media Disc Player	V	V																		V	V																																			
C	2015	Suburban	Body	Human Machine Interface Control Module	V	V																		V	V																								V											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																			
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
C	2015	Suburban	Body	HVAC Control Module	V	V																		V	V																																			
C	2015	Suburban	Body	Liftgate Control Module	V	V																			V																						V											
C	2015	Suburban	Body	Keyless Entry Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2015	Suburban	Body	Assist Step Control Module	V	V																		V	V																																			
C	2015	Suburban	Body	Left Side Object Detection Control Module	V																			V	V																																			
C	2015	Suburban	Body	Parking Assist Control Module	V																			V	V																																			
C	2015	Suburban	Body	Frontview Camera Module	V	V																			V																																			
C	2015	Suburban	Body	Steering Column Lock Control Module	V	V																			V																																			
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V													
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V												
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																		
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																		
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control	V	V																		V	V																																		
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																		
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1		V																			V																																		
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2		V																			V																																		
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																		
C	2015	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
C	2015	Tahoe	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		
C	2015	Tahoe	Chassis	Power Steering Control Module	V	V																		V	V																																		
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
C	2015	Tahoe	Chassis	Suspension Control Module	V	V																		V	V																																		
C	2015	Tahoe	Body	Body Control Module	V	V																		V	V																																		
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
C	2015	Tahoe	Body	Passenger Presence Module	V	V																			V																																		
C	2015	Tahoe	Body	Instrument Cluster	V	V																		V	V																																		
C	2015	Tahoe	Body	Radio Controls	V																				V																																		
C	2015	Tahoe	Body	HVAC Controls	V																			V	V																																		
C	2015	Tahoe	Body	Radio	V	V																		V	V																																		
C	2015	Tahoe	Body	Amplifier	V	V																			V																																		
C	2015	Tahoe	Body	Media Disc Player	V	V																		V	V																																		
C	2015	Tahoe	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																		
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
C	2015	Tahoe	Body	HVAC Control Module	V	V																		V	V																																		
C	2015	Tahoe	Body	Liftgate Control Module	V	V																			V																						V												
C	2015	Tahoe	Body	Keyless Entry Control Module	V	V																		V	V																																		
C	2015	Tahoe	Body	Assist Step Control Module	V	V																		V	V																																		
C	2015	Tahoe	Body	Left Side Object Detection Control Module	V																			V	V																																		
C	2015	Tahoe	Body	Parking Assist Control Module	V																			V	V																																		
C	2015	Tahoe	Body	Frontview Camera Module	V	V																		V	V																																		
C	2015	Tahoe	Body	Steering Column Lock Control Module	V	V																			V																																		
C	2015	Tahoe	Body	Battery Energy Control Module		V																			V																																		
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module	V																			V	V	V	V	V	V	V	V	V	V												V													
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																	
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V												
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module	V	V																		V	V																												V							
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module	V	V																			V																				V							V	V	V	V		
C	2016	Captiva (3GN)	Body	Body Control Module	V	V																		V	V																																			
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2016	Captiva (3GN)	Body	Instrument Cluster	V	V														V				V	V																																			
C	2016	Captiva (3GN)	Body	Radio	V	V																		V	V																																			
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
C	2016	Captiva (3GN)	Body	HVAC Control Module	V	V																		V	V																																			
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module	V	V																			V																																			
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
C	2016	Captiva (3GN)	Body	Parking Assist Control Module	V																			V	V																																			
C	2016	Captiva (3GN)	Body	Theft Deterrent Module	V	V																			V																																			
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission	V																			V	V						V																													
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission	V																			V	V						V																													
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module	V	V																		V	V										V			V																						
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V														V														
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V														V														
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission	V																			V	V			V			V														V														
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission	V																			V	V			V			V														V														
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																												
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V													V														
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V								V	V	V	V		V													
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V									V	V	V	V	V	V													
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
C	2016	Captiva (Other)	Powertrain	Chassis Control Module	V	V																		V	V							V		V																									
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																			
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module	V	V																		V	V																												V							V
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module	V	V																			V																				V							V	V	V	V		
C	2016	Captiva (Other)	Chassis	Power Steering Control Module	V	V																			V																																			
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto	V	V																		V	V																																			
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual	V	V																		V	V																																			
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module	V	V																		V	V																																			
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2016	Captiva (Other)	Body	Instrument Cluster	V	V																		V	V																																			
C	2016	Captiva (Other)	Body	Headlamp Control Module	V	V																		V	V																																			
C	2016	Captiva (Other)	Body	Radio	V	V																		V	V																																			
C	2016	Captiva (Other)	Body	HVAC Control Module	V																			V	V																																			
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module	V																			V	V																																			
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module	V																			V	V																																			
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)	V	V																		V	V																																			
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)	V	V																		V	V																																			
C	2016	Captiva (Other)	Body	Theft Deterrent Module	V	V																			V																																			
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V												V														
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V														
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V										V	V	V	V		V																			
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module	V	V																		V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																			
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)	V	V																		V	V																																			
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
C	2016	Cheyenne	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V							
C	2016	Cheyenne	Chassis	Power Steering Control Module	V	V																		V	V																																			
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2016	Cheyenne	Chassis	Suspension Control Module	V	V																		V	V																																			
C	2016	Cheyenne	Body	Body Control Module	V	V																		V	V																																			
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2016	Cheyenne	Body	Passenger Presence Module	V	V																			V																																			
C	2016	Cheyenne	Body	Instrument Cluster	V	V																		V	V																																			
C	2016	Cheyenne	Body	Radio Controls	V																				V																																			
C	2016	Cheyenne	Body	HVAC Controls	V																			V	V																																			
C	2016	Cheyenne	Body	Radio	V	V																		V	V																																			
C	2016	Cheyenne	Body	Amplifier	V	V																			V																																			
C	2016	Cheyenne	Body	Media Disc Player	V	V																		V	V																																			
C	2016	Cheyenne	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
C	2016	Cheyenne	Body	HVAC Control Module	V	V																		V	V																																			
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module	V	V																		V	V																																			
C	2016	Cheyenne	Body	Parking Assist Control Module	V																			V	V																																			
C	2016	Cheyenne	Body	Frontview Camera Module	V	V																		V	V																																			
C	2016	Cheyenne	Body	Frontview Camera Module	V	V																		V	V																																			
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V									V	V	V	V										V												
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V														
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																			
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module	V	V																		V	V									V	V	V	V		V																			
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module	V	V	V	V																V	V																																			
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2	V	V																		V	V																																			
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module	V	V																		V																																			
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V														
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																			
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module	V																			V	V					V		V																											
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module		V								V					V					V	V																																			
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module	V	V																		V	V									V	V	V	V		V																			
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																			
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																			
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)	V	V																		V	V																																			
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
C	2016	Silverado	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2016	Silverado	Chassis	Power Steering Control Module	V	V																			V																																			
C	2016	Silverado	Chassis	Power Steering Control Module	V	V																		V	V																																			
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2016	Silverado	Chassis	Suspension Control Module	V	V																		V	V																																			
C	2016	Silverado	Body	Body Control Module	V	V																		V	V																																			
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2016	Silverado	Body	Passenger Presence Module	V	V																			V																																			
C	2016	Silverado	Body	Instrument Cluster	V	V																		V	V																																			
C	2016	Silverado	Body	Radio Controls	V																				V																																			
C	2016	Silverado	Body	HVAC Controls	V																			V	V																																			
C	2016	Silverado	Body	Radio (IO3)	V	V																		V	V																																			
C	2016	Silverado	Body	Radio (IOB)	V	V																		V	V																																			
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)	V	V																		V	V																																			
C	2016	Silverado	Body	Amplifier	V	V																			V																																			
C	2016	Silverado	Body	Media Disc Player	V	V																		V	V																																			
C	2016	Silverado	Body	Human Machine Interface Control Module	V	V																		V	V																								V											
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																			
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
C	2016	Silverado	Body	Seat Memory Control Module - Driver	V																																																						
C	2016	Silverado	Body	Assist Step Object Detection Control Module	V	V																		V	V																																			
C	2016	Silverado	Body	Parking Assist Control Module	V																			V	V																																			
C	2016	Silverado	Body	Frontview Camera Module	V	V																		V	V																																			
C	2016	Silverado	Body	Frontview Camera Module	V	V																		V	V																																			
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V													
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V													V													
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
C	2016	Suburban	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
C	2016	Suburban	Chassis	Parking Brake Control Module	V	V																			V																							V							V	V	V	V		
C	2016	Suburban	Chassis	Power Steering Control Module	V	V																		V	V																																			
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2016	Suburban	Chassis	Suspension Control Module	V	V																		V	V																																			
C	2016	Suburban	Body	Body Control Module	V	V																		V	V																																			
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2016	Suburban	Body	Passenger Presence Module	V	V																			V																																			
C	2016	Suburban	Body	Instrument Cluster	V	V																		V	V																																			
C	2016	Suburban	Body	Radio Controls	V																				V																																			
C	2016	Suburban	Body	HVAC Controls	V																			V	V																																			
C	2016	Suburban	Body	Radio	V	V																		V	V																																			
C	2016	Suburban	Body	Amplifier	V	V																			V																																			
C	2016	Suburban	Body	Media Disc Player	V	V																		V	V																																			
C	2016	Suburban	Body	Human Machine Interface Control Module	V	V																		V	V																								V											
C	2016	Suburban	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
C	2016	Suburban	Body	HVAC Control Module	V	V																		V	V																																			
C	2016	Suburban	Body	Liftgate Control Module	V	V																		V	V																								V											

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2016	Suburban	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
C	2016	Suburban	Body	Seat Memory Control Module - Driver	V																																																							
C	2016	Suburban	Body	Keyless Entry Control Module	V	V																		V	V																																			
C	2016	Suburban	Body	Assist Step Control Module	V	V																		V	V																																			
C	2016	Suburban	Body	Left Side Object Detection Control Module	V																			V	V																																			
C	2016	Suburban	Body	Parking Assist Control Module	V																			V	V																																			
C	2016	Suburban	Body	Frontview Camera Module	V	V																		V	V																																			
C	2016	Suburban	Body	Steering Column Lock Control Module	V	V																			V																																			
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V			V	V	V	V	V													V															
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
C	2016	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
C	2016	Tahoe	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
C	2016	Tahoe	Chassis	Power Steering Control Module	V	V																		V	V																																			
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
C	2016	Tahoe	Chassis	Suspension Control Module	V	V																		V	V																																			
C	2016	Tahoe	Body	Body Control Module	V	V																		V	V																																			
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2016	Tahoe	Body	Passenger Presence Module	V	V																			V																																			
C	2016	Tahoe	Body	Instrument Cluster	V	V																		V	V																																			
C	2016	Tahoe	Body	Radio Controls	V																				V																																			
C	2016	Tahoe	Body	HVAC Controls	V																			V	V																																			
C	2016	Tahoe	Body	Radio	V	V																		V	V																																			
C	2016	Tahoe	Body	Amplifier	V	V																			V																																			
C	2016	Tahoe	Body	Media Disc Player	V	V																		V	V																																			
C	2016	Tahoe	Body	Human Machine Interface Control Module	V	V																		V	V																					V														
C	2016	Tahoe	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
C	2016	Tahoe	Body	HVAC Control Module	V	V																		V	V																																			
C	2016	Tahoe	Body	Liftgate Control Module	V	V																		V	V																					V														
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
C	2016	Tahoe	Body	Seat Memory Control Module - Driver	V																																																							
C	2016	Tahoe	Body	Keyless Entry Control Module	V	V																		V	V																																			
C	2016	Tahoe	Body	Assist Step Control Module	V	V																		V	V																																			
C	2016	Tahoe	Body	Left Side Object Detection Control Module	V																			V	V																																			
C	2016	Tahoe	Body	Parking Assist Control Module	V																			V	V																																			
C	2016	Tahoe	Body	Frontview Camera Module	V	V																		V	V																																			
C	2016	Tahoe	Body	Steering Column Lock Control Module	V	V																			V																																			
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module	V	V																		V	V							V																												
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module	V	V																		V	V							V																												
E	2004	ALL	Chassis	Electronic Brake Control Module	V																																																						
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module	V	V																		V	V							V																												
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module	V	V																		V	V							V																												
E	2006	ALL	Chassis	Electronic Brake Control Module	V	V																			V																																			
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module	V	V																		V	V							V																												
E	2007	ALL	Chassis	Electronic Brake Control Module	V	V																			V																																			
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V			V	V							V													V															
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V											V	V																							
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V			V	V							V													V															
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V											V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V															
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																								
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V			V	V							V													V															
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V											V	V																								
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V			V	V							V													V															
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V											V	V																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V															
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V											V	V																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V															
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V											V	V																								
G	2004	Express/Savana	Chassis	Anti-lock Brake System	V	V																		V	V																																			
G	2004	Express/Savana	Chassis	VSES	V	V																		V	V																																			
G	2004	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
G	2004	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2004	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																			
G	2004	Express/Savana	Body	OnStar	V	V																		V	V																																			
G	2004	Express/Savana	Body	Base Radio	V	V																			V																																			
G	2004	Express/Savana	Body	Uplevel Radio	V	V																			V																																			
G	2004	Express/Savana	Body	Remote Function Actuation	V	V																																																					
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V			V	V							V													V															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V											V	V																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V			V	V							V													V															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V											V	V																								
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V															
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																								
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V													V															
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V											V	V																								
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V			V	V							V													V															
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V											V	V																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V											V	V																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V											V	V																								
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System	V	V																		V	V																																			
G	2004	Express Access/Savana Pro	Chassis	VSES	V	V																		V	V																																			
G	2004	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																			
G	2004	Express Access/Savana Pro	Body	OnStar	V	V																		V	V																																			
G	2004	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																			
G	2004	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																			
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation	V	V																																																					
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																					
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V															
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V															
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control	V	V																		V											V	V																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V															
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control	V	V																		V											V	V																								
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module	V	V										V	V				V	V		V	V							V													V															

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module	V	V																		V											V	V																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V														V													
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V											V	V																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V														V													
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V											V	V																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V														V													
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V											V	V																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V														V													
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V											V	V																								
G	2005	Express/Savana	Chassis	Anti-lock Brake System	V	V																		V	V																																			
G	2005	Express/Savana	Chassis	VSES	V	V																		V	V																																			
G	2005	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
G	2005	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2005	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																			
G	2005	Express/Savana	Body	Base Radio	V	V																			V																																			
G	2005	Express/Savana	Body	Uplevel Radio	V	V																			V																																			
G	2005	Express/Savana	Body	Remote Function Actuation	V	V																																																					
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																					
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V														V													
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control	V	V																		V											V	V																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V														V													
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control	V	V																		V											V	V																								
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module	V	V																		V											V	V																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V														V													
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V											V	V																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V														V													
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V											V	V																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V														V													
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V											V	V																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V														V													
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V											V	V																								
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System	V	V																		V	V																																			
G	2005	Express Access/Savana Pro	Chassis	VSES	V	V																		V	V																																			
G	2005	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																			
G	2005	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																			
G	2005	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																			
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation	V	V																																																					
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																					
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V														V													
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control	V	V																		V											V	V																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V														V													
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control	V	V																		V											V	V																								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V																		V																																			
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V											V	V																							
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display		V																		V	V																																		
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display		V																		V	V																																		
G	2006	Express/Savana	Chassis	Anti-lock Brake System	V	V																		V	V																																		
G	2006	Express/Savana	Chassis	VSES	V	V																		V	V																																		
G	2006	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
G	2006	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
G	2006	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																		
G	2006	Express/Savana	Body	Passenger Presence System																																																						
G	2006	Express/Savana	Body	Base Radio	V	V																			V																																	
G	2006	Express/Savana	Body	Uplevel Radio	V	V																			V																																	
G	2006	Express/Savana	Body	Remote Function Actuation	V	V																																																			
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																			
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module	V	V																		V	V																																	
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V																		V																																			
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display		V																		V	V																																		
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display		V																		V	V																																		
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System	V	V																		V	V																																		
G	2006	Express Access/Savana Pro	Chassis	VSES	V	V																		V	V																																		
G	2006	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																		
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																						
G	2006	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																	
G	2006	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																	
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation	V	V																																																			
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V														
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V															V			V																																				
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display		V																		V	V																																			
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display		V																		V	V																																			
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display		V																		V	V																																			
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display		V																		V	V																																			
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2007	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
G	2007	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2007	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																			
G	2007	Express/Savana	Body	Passenger Presence System																																																							
G	2007	Express/Savana	Body	Base Radio	V	V																			V																																			
G	2007	Express/Savana	Body	Uplevel Radio	V	V																			V																																			
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																																																					
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																					
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V											V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V															V			V																																				
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V											V	V																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display		V																		V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display		V																		V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V															
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V											V	V																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display		V																		V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display		V																		V	V																																			
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2007	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																			
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2007	Express Access/Savana Pro	Body	Radio	V	V																			V																																			
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																			V																																			
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																																																					
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																					
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V															
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V															
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V											V	V																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V															
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V															
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V											V	V																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V						V			V	V																																			
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V	V										V	V																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2008	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
G	2008	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2008	Express/Savana	Body	Passenger Presence System	V	V																			V																																			
G	2008	Express/Savana	Body	Radio	V	V																		V	V																																			
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
G	2008	Express/Savana	Body	Rollover Sensor	V	V																			V																																			
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2008	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																			
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V															
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V															
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V											V	V																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V															
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																								
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V															

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V						V			V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V																									
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2008	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2008	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																			
G	2008	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																			
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
G	2008	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																			
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																			
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																									
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																									
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V													
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																			
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V																									
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2009	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
G	2009	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2009	Express/Savana	Body	Passenger Presence System	V	V																			V																																			
G	2009	Express/Savana	Body	Radio	V	V																		V	V																																			
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
G	2009	Express/Savana	Body	Rollover Sensor	V	V																			V																																			
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2009	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																			
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																									
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V													
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																			
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																			
G	2009	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																			
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																			
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																						
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V																		V	V																																			
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																							
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																						
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																			
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																			
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V											V	V	V																						
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																			
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V											V	V	V																						
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2010	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
G	2010	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2010	Express/Savana	Body	Passenger Presence System	V	V																			V																																			
G	2010	Express/Savana	Body	Radio	V	V																		V	V																																			
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
G	2010	Express/Savana	Body	Rollover Sensor	V	V																			V																																			
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2010	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																			
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																						
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																							
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																						
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																			
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																			
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V											V	V	V																						
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module		V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																			
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																							
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2010	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2010	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																			
G	2010	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																			
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
G	2010	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																			
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																			
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																							
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V														
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																							
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																			
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																			
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																							
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2011	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
G	2011	Express/Savana	Body	Digital Radio Receiver	V	V																		V	V																																			
G	2011	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2011	Express/Savana	Body	Passenger Presence System	V	V																			V																																			
G	2011	Express/Savana	Body	Radio	V	V																		V	V																																			
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
G	2011	Express/Savana	Body	Rollover Sensor	V	V																			V																																			
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2011	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																			
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																							
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V														
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																							
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																		
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																		
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																						
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
G	2011	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver	V	V																		V	V																																		
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
G	2011	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																		
G	2011	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																		
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
G	2011	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																		
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																		
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																		
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V												
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																						
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V														V												
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																						
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																		
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																		
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																		
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																						
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
G	2012	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
G	2012	Express/Savana	Body	Digital Radio Receiver	V	V																		V	V																																		
G	2012	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
G	2012	Express/Savana	Body	Passenger Presence System	V	V																			V																																		
G	2012	Express/Savana	Body	Radio	V	V																		V	V																																		
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
G	2012	Express/Savana	Body	Rollover Sensor	V	V																			V																																		
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																		
G	2012	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																		
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V												
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																						
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V														V												
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																		
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																		
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V											V	V	V																						
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
G	2012	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver	V	V																		V	V																																		
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
G	2012	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																		
G	2012	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																		
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
G	2012	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																		
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																		
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																		
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V		V	V			V	V							V													V													
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																						
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																						
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																						
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																						
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V													
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V											V	V	V																						
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																		
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																		
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																		
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V											V	V	V																						
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
G	2013	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
G	2013	Express/Savana	Body	Digital Radio Receiver	V	V																		V	V																																		
G	2013	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
G	2013	Express/Savana	Body	Navigation Radio	V	V																		V	V																																		
G	2013	Express/Savana	Body	Park Assist Module	V	V																			V																																		
G	2013	Express/Savana	Body	Passenger Presence System	V	V																			V																																		
G	2013	Express/Savana	Body	Radio	V	V																		V	V																																		
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
G	2013	Express/Savana	Body	Rollover Sensor	V	V																			V																																		
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																		
G	2013	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																		
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V		V	V			V	V							V													V													
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																						
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																						
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																						
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V													
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																						
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																	
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																	
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																	
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																						
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																	
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																	
G	2013	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																	
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver	V	V																		V	V																																	
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																	
G	2013	Express Access/Savana Pro	Body	Navigation Radio	V	V																		V	V																																	
G	2013	Express Access/Savana Pro	Body	Park Assist Module	V	V																			V																																	
G	2013	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																	
G	2013	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																	
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
G	2013	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																	
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																	
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																	
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module	V																			V	V			V	V	V	V	V													V													
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module	V	V																		V	V									V	V	V	V	V								V													
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module	V																			V	V	V		V	V	V	V	V													V													
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module	V	V																		V	V									V		V	V									V													
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module	V																			V	V	V		V	V	V	V	V													V													
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module	V	V																		V	V							V		V																								
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module	V	V																		V	V									V	V	V	V	V									V												
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V		V	V	V	V	V													V													
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V		V	V									V													
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V	V		V	V	V	V	V													V													
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V		V	V									V													
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V					V		V																									
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																	
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V									V		V	V									V													
G	2014	Express	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						V
G	2014	Express	Body	Body Control Module	V	V																		V	V																																	
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
G	2014	Express	Body	Passenger Presence Module	V	V																			V																																	
G	2014	Express	Body	Rollover Sensor Module	V	V																			V																																	
G	2014	Express	Body	Instrument Cluster	V	V																		V	V																																	
G	2014	Express	Body	Chime Alarm Control Module	V																			V	V																																	
G	2014	Express	Body	Base Radio	V	V																		V	V																																	
G	2014	Express	Body	Navigation Radio	V	V																		V	V																																	
G	2014	Express	Body	Uplevel Radio	V	V																		V	V																																	
G	2014	Express	Body	Digital Radio Receiver Control Module	V	V																		V	V																																	
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
G	2014	Express	Body	Auxiliary Heater Control Module		V																		V																																	
G	2014	Express	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
G	2014	Express	Body	Parking Assist Control Module	V																			V	V																																	
G	2014	Express	Body	Theft Deterrent Module	V	V																			V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module	V																		V	V				V	V	V	V	V												V															
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module	V	V																	V	V										V	V	V	V	V								V													
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module	V																		V	V	V			V	V	V	V	V												V														
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module	V	V																	V	V										V	V	V	V								V													
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module	V																		V	V	V			V	V	V	V	V												V													
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module	V	V																	V	V							V		V																								
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module	V	V																	V	V										V	V	V	V	V								V													
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module	V																		V	V	V			V	V	V	V	V												V													
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																	V	V										V	V	V	V								V													
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module	V																		V	V	V			V	V	V	V	V												V													
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																	V	V										V	V	V	V								V													
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V																		V	V						V		V																									
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V							V					V					V	V																																	
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																	V	V										V	V	V	V								V													
G	2014	Savana	Chassis	Electronic Brake Control Module	V	V																	V	V													V									V	V	V	V	V	V						V
G	2014	Savana	Body	Body Control Module	V	V																	V	V																																	
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V																																
G	2014	Savana	Body	Passenger Presence Module	V	V																		V																																
G	2014	Savana	Body	Rollover Sensor Module	V	V																		V																																
G	2014	Savana	Body	Instrument Cluster	V	V																	V	V																																
G	2014	Savana	Body	Chime Alarm Control Module	V																		V	V																																
G	2014	Savana	Body	Base Radio	V	V																	V	V																																
G	2014	Savana	Body	Navigation Radio	V	V																	V	V																																
G	2014	Savana	Body	Uplevel Radio	V	V																	V	V																																
G	2014	Savana	Body	Digital Radio Receiver Control Module	V	V																	V	V																																
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9	V	V																	V	V																																
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																
G	2014	Savana	Body	Auxiliary Heater Control Module		V																	V																																	
G	2014	Savana	Body	Remote Control Door Lock Receiver	V	V																	V	V																																
G	2014	Savana	Body	Parking Assist Control Module	V																		V	V																																
G	2014	Savana	Body	Theft Deterrent Module	V	V																		V																																
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module	V																		V	V	V			V	V	V	V	V												V														
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module	V	V																	V	V										V	V	V	V								V													
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module	V																		V	V	V			V	V	V	V	V												V													
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																	V	V										V	V	V	V								V													
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module	V																		V	V	V			V	V	V	V	V												V													
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																	V	V										V	V	V	V								V													
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module	V																		V	V						V		V																									
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V							V					V					V	V																																	
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																	V	V										V	V	V	V								V													
G	2015	Express	Chassis	Electronic Brake Control Module	V	V																	V	V													V									V	V	V	V	V	V						V
G	2015	Express	Body	Body Control Module	V	V																	V	V																																	
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V																																
G	2015	Express	Body	Rollover Sensor Module	V	V																		V																																
G	2015	Express	Body	Instrument Cluster	V	V																	V	V																																
G	2015	Express	Body	Digital Radio Receiver Control Module	V	V																	V	V																																
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9	V	V																	V	V																																
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																
G	2015	Express	Body	Auxiliary Heater Control Module		V																	V																																	
G	2015	Express	Body	Remote Control Door Lock Receiver	V	V																	V	V																																
G	2015	Express	Body	Parking Assist Control Module	V																		V	V																																

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2015	Express	Body	Theft Deterrent Module	V	V																			V																																			
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V												V															
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V												V															
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V	V			V	V	V	V	V												V															
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																										
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																		
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V									V	V	V	V									V														
G	2015	Savana	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
G	2015	Savana	Body	Body Control Module	V	V																		V	V																																		
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
G	2015	Savana	Body	Rollover Sensor Module	V	V																			V																																	
G	2015	Savana	Body	Instrument Cluster	V	V																		V	V																																	
G	2015	Savana	Body	Digital Radio Receiver Control Module	V	V																		V	V																																	
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
G	2015	Savana	Body	Auxiliary Heater Control Module		V																		V																																	
G	2015	Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
G	2015	Savana	Body	Parking Assist Control Module	V																			V	V																																	
G	2015	Savana	Body	Theft Deterrent Module	V	V																			V																																	
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V												V															
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V												V															
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V												V															
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																										
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																		
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V									V	V	V	V									V														
G	2016	Express	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
G	2016	Express	Body	Body Control Module	V	V																		V	V																																	
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
G	2016	Express	Body	Instrument Cluster	V	V																		V	V																																	
G	2016	Express	Body	Chime Alarm Control Module	V																			V	V																																	
G	2016	Express	Body	Base Radio	V	V																		V	V																																	
G	2016	Express	Body	Navigation Radio	V	V																		V	V																																	
G	2016	Express	Body	Uplevel Radio	V	V																		V	V																																	
G	2016	Express	Body	Digital Radio Receiver Control Module	V	V																		V	V																																	
G	2016	Express	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
G	2016	Express	Body	Auxiliary Heater Control Module		V																		V																																	
G	2016	Express	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
G	2016	Express	Body	Parking Assist Control Module	V																			V	V																																	
G	2016	Express	Body	Theft Deterrent Module	V	V																			V																																	
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V												V															
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V												V															
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V												V															
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V									V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																											
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																			
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V									V	V	V	V									V													
G	2016	Savana	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
G	2016	Savana	Body	Body Control Module	V	V																		V	V																																		
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
G	2016	Savana	Body	Instrument Cluster	V	V																		V	V																																	
G	2016	Savana	Body	Chime Alarm Control Module	V																			V	V																																	
G	2016	Savana	Body	Digital Radio Receiver Control Module	V	V																		V	V																																	
G	2016	Savana	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
G	2016	Savana	Body	Auxiliary Heater Control Module		V																		V																																	
G	2016	Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
G	2016	Savana	Body	Parking Assist Control Module	V																			V	V																																	
G	2016	Savana	Body	Theft Deterrent Module	V	V																			V																																	
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V			V	V							V													V													
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																							
H	2004	Express/Savana	Chassis	Anti-lock Brake System	V	V																		V	V																																	
H	2004	Express/Savana	Chassis	VSES	V	V																		V	V																																	
H	2004	Express/Savana	Body	Body Control Module	V	V																		V	V																																	
H	2004	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																	
H	2004	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																	
H	2004	Express/Savana	Body	OnStar	V	V																		V	V																																	
H	2004	Express/Savana	Body	Base Radio	V	V																			V																																	
H	2004	Express/Savana	Body	Uplevel Radio	V	V																			V																																	
H	2004	Express/Savana	Body	Remote Function Actuation	V	V																																																				
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																				
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V			V	V							V													V													
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																							
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System	V	V																		V	V																																	
H	2004	Express Access/Savana Pro	Chassis	VSES	V	V																		V	V																																	
H	2004	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																	
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																	
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																	
H	2004	Express Access/Savana Pro	Body	OnStar	V	V																		V	V																																	
H	2004	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																	
H	2004	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																	
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation	V	V																																																			
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																			
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V													
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																							
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V													
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																							
H	2005	Express/Savana	Chassis	Anti-lock Brake System	V	V																		V	V																																	
H	2005	Express/Savana	Chassis	VSES	V	V																		V	V																																	
H	2005	Express/Savana	Body	Body Control Module	V	V																		V	V																																	
H	2005	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																	
H	2005	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																	
H	2005	Express/Savana	Body	Base Radio	V	V																			V																																	
H	2005	Express/Savana	Body	Uplevel Radio	V	V																			V																																	
H	2005	Express/Savana	Body	Remote Function Actuation	V	V																																																			
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																									
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System	V	V																		V	V																																			
H	2005	Express Access/Savana Pro	Chassis	VSES	V	V																		V	V																																			
H	2005	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																			
H	2005	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																			
H	2005	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																			
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation	V	V																																																					
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																					
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																									
H	2006	Express/Savana	Chassis	Anti-lock Brake System	V	V																		V	V																																			
H	2006	Express/Savana	Chassis	VSES	V	V																		V	V																																			
H	2006	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
H	2006	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2006	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																			
H	2006	Express/Savana	Body	Passenger Presence System																																																							
H	2006	Express/Savana	Body	Base Radio	V	V																			V																																			
H	2006	Express/Savana	Body	Uplevel Radio	V	V																			V																																			
H	2006	Express/Savana	Body	Remote Function Actuation	V	V																																																					
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																					
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																									
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System	V	V																		V	V																																			
H	2006	Express Access/Savana Pro	Chassis	VSES	V	V																		V	V																																			
H	2006	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																			
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																							
H	2006	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																			
H	2006	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																			
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation	V	V																																																					
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																					
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2007	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
H	2007	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2007	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																		
H	2007	Express/Savana	Body	Passenger Presence System																																																						
H	2007	Express/Savana	Body	Base Radio	V	V																			V																																		
H	2007	Express/Savana	Body	Uplevel Radio	V	V																			V																																		
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																																																				
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																				
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V						V														V													
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																							
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V						V														V													
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																							
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V						V														V													
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																							
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2007	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																		
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																					
H	2007	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																		
H	2007	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																		
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																																																			
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																			
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V													
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V						V													V													
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																							
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V			V	V		V	V						V													V													
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																	
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V						V													V													
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																							
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2008	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
H	2008	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2008	Express/Savana	Body	Passenger Presence System	V	V																			V																																		
H	2008	Express/Savana	Body	Radio	V	V																		V	V																																		
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2008	Express/Savana	Body	Rollover Sensor	V	V																			V																																		
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																		
H	2008	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																		
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V													
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V						V													V													
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V													
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																								
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2008	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2008	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																		
H	2008	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																		
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2008	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																		
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																		
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																		
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																								
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2009	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
H	2009	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2009	Express/Savana	Body	Passenger Presence System	V	V																			V																																		
H	2009	Express/Savana	Body	Radio	V	V																		V	V																																		
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2009	Express/Savana	Body	Rollover Sensor	V	V																			V																																		
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																		
H	2009	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																		
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																								
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2009	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2009	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																		
H	2009	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																		
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2009	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																			
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																			
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																						
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V																		V	V																																		
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																							
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																						
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2010	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
H	2010	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2010	Express/Savana	Body	Passenger Presence System	V	V																			V																																		
H	2010	Express/Savana	Body	Radio	V	V																		V	V																																		
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2010	Express/Savana	Body	Rollover Sensor	V	V																			V																																		
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																		
H	2010	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																		
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																						
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																							
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																						
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2010	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2010	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																		
H	2010	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																		
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2010	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																		
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																		
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																		
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																						
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																							
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																						
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V														V													
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V											V	V	V																						
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2011	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
H	2011	Express/Savana	Body	Digital Radio Receiver	V	V																		V	V																																		
H	2011	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2011	Express/Savana	Body	Passenger Presence System	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2011	Express/Savana	Body	Radio	V	V																		V	V																																			
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2011	Express/Savana	Body	Rollover Sensor	V	V																			V																																		
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																		
H	2011	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																		
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																						
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V						V														V													
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																						
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2011	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver	V	V																		V	V																																		
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2011	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																		
H	2011	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																		
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2011	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																		
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																		
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																		
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																						
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V						V														V													
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																						
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2012	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
H	2012	Express/Savana	Body	Digital Radio Receiver	V	V																		V	V																																		
H	2012	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2012	Express/Savana	Body	Passenger Presence System	V	V																			V																																		
H	2012	Express/Savana	Body	Radio	V	V																		V	V																																		
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2012	Express/Savana	Body	Rollover Sensor	V	V																			V																																		
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																		
H	2012	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																		
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																						
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V													
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																						
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																	
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																	
H	2012	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																	
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver	V	V																		V	V																																	
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																	
H	2012	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																	
H	2012	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																	
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
H	2012	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																	
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																	
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																	
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																						
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																	
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V													
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																						
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																	
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																	
H	2013	Express/Savana	Body	Body Control Module	V	V																		V	V																																	
H	2013	Express/Savana	Body	Digital Radio Receiver	V	V																		V	V																																	
H	2013	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																	
H	2013	Express/Savana	Body	Navigation Radio	V	V																		V	V																																	
H	2013	Express/Savana	Body	Park Assist Module	V	V																			V																																	
H	2013	Express/Savana	Body	Passenger Presence System	V	V																			V																																	
H	2013	Express/Savana	Body	Radio	V	V																		V	V																																	
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
H	2013	Express/Savana	Body	Rollover Sensor	V	V																			V																																	
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																	
H	2013	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																	
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																						
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																	
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V													
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																						
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																	
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																	
H	2013	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																	
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver	V	V																		V	V																																	
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																	
H	2013	Express Access/Savana Pro	Body	Navigation Radio	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2013	Express Access/Savana Pro	Body	Park Assist Module	V	V																			V																																			
H	2013	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																			
H	2013	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																			
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
H	2013	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																			
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																			
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																			
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module	V																			V	V			V	V	V	V	V														V														
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module	V	V																		V	V									V	V	V	V	V								V														
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module	V																			V	V	V		V	V	V	V	V														V														
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module	V	V																		V	V									V		V	V									V														
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module	V																			V	V	V		V	V	V	V	V														V														
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module	V	V																		V	V						V		V																											
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module	V	V																		V	V									V	V	V	V	V								V														
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V		V	V	V	V	V														V														
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V		V	V									V														
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V	V		V	V	V	V	V														V														
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V		V	V									V														
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																											
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																			
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V									V		V	V									V														
H	2014	Express	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V					V
H	2014	Express	Body	Body Control Module	V	V																		V	V																																		
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
H	2014	Express	Body	Passenger Presence Module	V	V																			V																																			
H	2014	Express	Body	Rollover Sensor Module	V	V																			V																																			
H	2014	Express	Body	Instrument Cluster	V	V																		V	V																																			
H	2014	Express	Body	Chime Alarm Control Module	V																			V	V																																			
H	2014	Express	Body	Base Radio	V	V																		V	V																																			
H	2014	Express	Body	Navigation Radio	V	V																		V	V																																			
H	2014	Express	Body	Uplevel Radio	V	V																		V	V																																			
H	2014	Express	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
H	2014	Express	Body	Auxiliary Heater Control Module		V																		V																																				
H	2014	Express	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
H	2014	Express	Body	Parking Assist Control Module	V																			V	V																																			
H	2014	Express	Body	Theft Deterrent Module	V	V																			V																																			
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module	V																			V	V			V	V	V	V	V														V														
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module	V	V																		V	V									V	V	V	V	V								V														
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module	V																			V	V	V		V	V	V	V	V														V														
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module	V																			V	V	V		V	V	V	V	V														V														
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module	V	V																		V	V						V		V																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module	V	V																		V	V									V	V	V	V	V								V														
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V		V	V	V	V	V														V														
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V	V		V	V	V	V	V														V														
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																											
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V									V	V	V	V									V													
H	2014	Savana	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
H	2014	Savana	Body	Body Control Module	V	V																		V	V																																		
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
H	2014	Savana	Body	Passenger Presence Module	V	V																			V																																	
H	2014	Savana	Body	Rollover Sensor Module	V	V																			V																																	
H	2014	Savana	Body	Instrument Cluster	V	V																		V	V																																	
H	2014	Savana	Body	Chime Alarm Control Module	V																			V	V																																	
H	2014	Savana	Body	Base Radio	V	V																		V	V																																	
H	2014	Savana	Body	Navigation Radio	V	V																		V	V																																	
H	2014	Savana	Body	Uplevel Radio	V	V																		V	V																																	
H	2014	Savana	Body	Digital Radio Receiver Control Module	V	V																		V	V																																	
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
H	2014	Savana	Body	Auxiliary Heater Control Module		V																		V																																	
H	2014	Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
H	2014	Savana	Body	Parking Assist Control Module	V																			V	V																																	
H	2014	Savana	Body	Theft Deterrent Module	V	V																			V																																	
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module	V	V																		V	V									V	V	V	V									V												
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V												
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V									V												
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																								
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																	
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V									V	V	V	V									V												
H	2015	Express	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
H	2015	Express	Body	Body Control Module	V	V																		V	V																																	
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
H	2015	Express	Body	Rollover Sensor Module	V	V																			V																																	
H	2015	Express	Body	Instrument Cluster	V	V																		V	V																																	
H	2015	Express	Body	Digital Radio Receiver Control Module	V	V																		V	V																																	
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
H	2015	Express	Body	Auxiliary Heater Control Module		V																		V																																	
H	2015	Express	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
H	2015	Express	Body	Parking Assist Control Module	V																			V	V																																	
H	2015	Express	Body	Theft Deterrent Module	V	V																			V																																	
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module	V	V																		V	V									V	V	V	V									V												
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V												
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V									V												
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																								
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																	
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V									V	V	V	V									V												
H	2015	Savana	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
H	2015	Savana	Body	Body Control Module	V	V																		V	V																																	
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2015	Savana	Body	Rollover Sensor Module	V	V																			V																																			
H	2015	Savana	Body	Instrument Cluster	V	V																		V	V																																		
H	2015	Savana	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
H	2015	Savana	Body	Auxiliary Heater Control Module		V																		V																																			
H	2015	Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2015	Savana	Body	Parking Assist Control Module	V																			V	V																																		
H	2015	Savana	Body	Theft Deterrent Module	V	V																			V																																		
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V													V													
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V													V												
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																									
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																		
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V										V	V	V	V									V												
H	2016	Express	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
H	2016	Express	Body	Body Control Module	V	V																		V	V																																		
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
H	2016	Express	Body	Instrument Cluster	V	V																		V	V																																		
H	2016	Express	Body	Chime Alarm Control Module	V																			V	V																																		
H	2016	Express	Body	Base Radio	V	V																		V	V																																		
H	2016	Express	Body	Navigation Radio	V	V																		V	V																																		
H	2016	Express	Body	Uplevel Radio	V	V																		V	V																																		
H	2016	Express	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
H	2016	Express	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
H	2016	Express	Body	Auxiliary Heater Control Module		V																		V																																			
H	2016	Express	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2016	Express	Body	Parking Assist Control Module	V																			V	V																																		
H	2016	Express	Body	Theft Deterrent Module	V	V																			V																																		
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V													V												
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																									
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																		
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V										V	V	V	V									V												
H	2016	Savana	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
H	2016	Savana	Body	Body Control Module	V	V																		V	V																																		
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
H	2016	Savana	Body	Instrument Cluster	V	V																		V	V																																		
H	2016	Savana	Body	Chime Alarm Control Module	V																			V	V																																		
H	2016	Savana	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
H	2016	Savana	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
H	2016	Savana	Body	Auxiliary Heater Control Module		V																		V																																			
H	2016	Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2016	Savana	Body	Parking Assist Control Module	V																			V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2016	Savana	Body	Theft Deterrent Module	V	V																			V																																			
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module	V	V																		V	V							V																												
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module	V	V																		V	V							V																												
J	2004	ALL	Chassis	Electronic Brake Control Module	V																																																							
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module	V	V																		V	V							V																												
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module	V	V																		V	V							V																												
J	2007	ALL	Chassis	Electronic Brake Control Module	V	V																			V																																			
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V													
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)	V																			V	V				V	V	V	V												V	V													
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)	V																			V	V				V	V	V	V												V	V													
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V													
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)	V																			V	V				V	V	V	V												V	V													
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)	V																			V	V				V	V	V	V												V	V													
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																		
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																		
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)	V																			V	V																																		
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)	V																			V	V																																		
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V																			V	V																				V	V													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer	V																			V	V				V	V	V	V														V													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V																			V	V																				V	V													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer	V																			V	V				V	V	V	V												V	V													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer	V																			V	V																				V	V													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer	V																			V	V				V	V	V	V													V	V													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer	V																			V	V																					V													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer	V																			V	V				V	V	V	V													V	V													
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V													
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)	V																			V	V				V	V	V	V												V	V													
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)	V																			V	V				V	V	V	V													V													
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module	V	V																			V																						V												
J	2013	Tracker	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V							
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
J	2013	Tracker	Chassis	Power Steering Control Module	V	V																			V																																		
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
J	2013	Tracker	Body	Body Control Module	V	V																		V	V																																		
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
J	2013	Tracker	Body	Passenger Presence Module	V	V																			V																																		
J	2013	Tracker	Body	Instrument Cluster	V	V																		V	V																																		
J	2013	Tracker	Body	Radio	V	V																		V	V																																		
J	2013	Tracker	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
J	2013	Tracker	Body	Front Seat Heating Control Module	V	V																		V	V																																		
J	2013	Tracker	Body	Parking Assist Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2013	Tracker	Body	Frontview Camera Module	V	V																		V	V																																			
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module	V	V																		V	V							V		V																									
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																		
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																		
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)	V																			V	V																																		
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)	V																			V	V																																		
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V																			V	V																				V	V													
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer	V																			V	V				V	V	V	V														V													
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V																			V	V																				V	V													
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer	V																			V	V																				V	V													
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer	V																			V	V																					V													
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer	V																			V	V				V	V	V	V													V	V													
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module	V	V																			V																						V												
J	2013	Trax	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
J	2013	Trax	Chassis	Power Steering Control Module	V	V																			V																																		
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
J	2013	Trax	Body	Body Control Module	V	V																		V	V																																		
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
J	2013	Trax	Body	Passenger Presence Module	V	V																			V																																		
J	2013	Trax	Body	Instrument Cluster	V	V																		V	V																																		
J	2013	Trax	Body	Radio	V	V																		V	V																																		
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
J	2013	Trax	Body	Front Seat Heating Control Module	V	V																		V	V																																		
J	2013	Trax	Body	Parking Assist Control Module	V	V																		V	V																																		
J	2013	Trax	Body	Frontview Camera Module	V	V																		V	V																																		
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)	V																			V	V				V	V	V	V													V	V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)	V																		V	V				V	V	V	V													V	V															
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																				
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V																												
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V												V																
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)	V																		V	V				V	V	V	V												V	V															
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)	V																		V	V				V	V	V	V												V	V															
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module	V	V																	V	V							V		V																										
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V															
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																		V	V				V	V	V	V												V	V															
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)	V																		V	V				V	V	V	V												V	V															
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)	V																		V	V				V	V	V	V												V	V															
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																	
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																	
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)	V																			V	V																																	
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)	V																			V	V																																	
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module	V	V																		V	V								V	V	V	V	V	V																				
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V																			V	V																		V	V															
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer	V																			V	V				V	V	V	V												V															
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V																			V	V																		V	V															
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer	V																			V	V				V	V	V	V												V	V															
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer	V																			V	V																		V	V															
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer	V																			V	V				V	V	V	V												V	V															
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer	V																			V	V																			V															
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer	V																			V	V				V	V	V	V												V	V															
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V															
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)	V																			V	V				V	V	V	V												V	V															
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)	V																			V	V				V	V	V	V													V															
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module	V	V																			V																					V														
J	2014	Tracker	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V							
J	2014	Tracker	Chassis	Power Steering Control Module	V	V																			V																																		
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
J	2014	Tracker	Body	Body Control Module	V	V																		V	V																																		
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
J	2014	Tracker	Body	Passenger Presence Module	V	V																			V																																		
J	2014	Tracker	Body	Instrument Cluster	V	V																		V	V																																		
J	2014	Tracker	Body	Radio	V	V																		V	V																																		
J	2014	Tracker	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
J	2014	Tracker	Body	Front Seat Heating Control Module	V	V																		V	V																																		
J	2014	Tracker	Body	Parking Assist Control Module	V	V																		V	V																																		
J	2014	Tracker	Body	Frontview Camera Module	V	V																		V	V																																		
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V															
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V															

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module	V	V																		V	V							V		V																									
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																	
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																	
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V																			V	V																			V	V													
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer	V																			V	V				V	V	V	V														V													
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V																			V	V																			V	V													
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer	V																			V	V				V	V	V	V													V	V													
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2014	Trax	Powertrain	Fuel Injector Control Module		V																		V	V																																			
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module	V	V																			V																						V												
J	2014	Trax	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
J	2014	Trax	Chassis	Power Steering Control Module	V	V																			V																																		
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
J	2014	Trax	Body	Body Control Module	V	V																		V	V																																		
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
J	2014	Trax	Body	Passenger Presence Module	V	V																			V																																		
J	2014	Trax	Body	Instrument Cluster	V	V																		V	V																																		
J	2014	Trax	Body	Radio	V	V																		V	V																																		
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
J	2014	Trax	Body	Front Seat Heating Control Module	V	V																		V	V																																		
J	2014	Trax	Body	Parking Assist Control Module	V	V																		V	V																																		
J	2014	Trax	Body	Frontview Camera Module	V	V																		V	V																																		
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)	V																			V	V				V	V	V	V													V	V													
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)	V																			V	V				V	V	V	V													V	V													
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)	V																			V	V				V	V	V	V													V	V													
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)	V																			V	V				V	V	V	V													V	V													
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission	V																			V	V																																		
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission	V																			V	V																																		
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)	V																			V	V																																		
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)	V																			V	V																																		
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																		
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																		
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)	V																			V	V																																		
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)	V																			V	V																																		
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V																			V	V																			V	V													
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer	V																			V	V				V	V	V	V														V													
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V																			V	V																			V	V													
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer	V																			V	V				V	V	V	V													V	V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer	V																		V	V																			V	V														
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer	V																		V	V				V	V	V	V													V	V													
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer	V																		V	V																					V													
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer	V																		V	V				V	V	V	V													V	V													
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)	V																		V	V				V	V	V	V													V	V													
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)	V																		V	V				V	V	V	V														V													
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module	V	V																		V																						V											
J	2015	Tracker	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V						
J	2015	Tracker	Chassis	Power Steering Control Module	V	V																		V																																		
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module	V																			V																																		
J	2015	Tracker	Body	Body Control Module	V	V																	V	V																																		
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
J	2015	Tracker	Body	Instrument Cluster	V	V																	V	V																																		
J	2015	Tracker	Body	Telematics Communication Interface Control Module	V	V																	V	V																																		
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)	V	V																	V	V																																		
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)	V	V																	V	V																																		
J	2015	Tracker	Body	Front Seat Heating Control Module	V	V																	V	V																																		
J	2015	Tracker	Body	Parking Assist Control Module	V	V																	V	V																																		
J	2015	Tracker	Body	Frontview Camera Module	V	V																	V	V																																		
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission	V																		V	V																																		
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission	V																		V	V																																		
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V																																	
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V																																	
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission	V																			V	V																			V	V													
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission	V																			V	V																			V	V													
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																		
J	2015	Trax	Powertrain	Fuel Injector Control Module		V																		V	V																																	
J	2015	Trax	Powertrain	Chassis Control Module	V	V																		V	V						V		V																								
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module	V	V																			V																						V											
J	2015	Trax	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
J	2015	Trax	Chassis	Power Steering Control Module	V	V																			V																																	
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
J	2015	Trax	Body	Body Control Module	V	V																		V	V																																	
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
J	2015	Trax	Body	Passenger Presence Module	V	V																			V																																	
J	2015	Trax	Body	Instrument Cluster	V	V																		V	V																																	
J	2015	Trax	Body	Radio	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)	V	V																		V	V																																		
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
J	2015	Trax	Body	Seat Memory Control Module	V																																																					
J	2015	Trax	Body	Front Seat Heating Control Module	V	V																		V	V																																		
J	2015	Trax	Body	Right Side Object Detection Control Module	V																			V	V																																		
J	2015	Trax	Body	Left Side Object Detection Control Module	V																			V	V																																		
J	2015	Trax	Body	Parking Assist Control Module	V	V																		V	V																																		
J	2015	Trax	Body	Frontview Camera Module	V	V																		V	V																																		
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V																			V	V																				V	V													
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer	V																			V	V				V	V	V	V														V													
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V																			V	V																				V	V													
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer	V																			V	V				V	V	V	V													V	V													
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2016	Tracker	Powertrain	Fuel Injector Control Module		V																		V	V																																		
J	2016	Tracker	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V							
J	2016	Tracker	Chassis	Power Steering Control Module	V	V																			V																																	
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
J	2016	Tracker	Body	Body Control Module	V	V																		V	V																																		
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
J	2016	Tracker	Body	Instrument Cluster	V	V																		V	V																																		
J	2016	Tracker	Body	Trailer Interface Control Module	V	V																		V	V																																		
J	2016	Tracker	Body	Radio	V	V																		V	V																																		
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																		
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																		
J	2016	Tracker	Body	Front Seat Heating Control Module	V	V																		V	V																																		
J	2016	Tracker	Body	Parking Assist Control Module	V																			V	V																																		
J	2016	Tracker	Body	Frontview Camera Module	V	V																		V	V																																		
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																											
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V															
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V															
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission	V																			V	V																																		
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission	V																			V	V																																		
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V														
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
J	2016	Trax	Powertrain	Fuel Injector Control Module		V																		V	V																																		
J	2016	Trax	Powertrain	Chassis Control Module	V	V																		V	V							V		V																									
J	2016	Trax	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
J	2016	Trax	Chassis	Power Steering Control Module	V	V																			V																																	
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
J	2016	Trax	Body	Body Control Module	V	V																		V	V																																	
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
J	2016	Trax	Body	Passenger Presence Module	V	V																			V																																	
J	2016	Trax	Body	Instrument Cluster	V	V																		V	V																																	
J	2016	Trax	Body	Trailer Interface Control Module	V	V																		V	V																																	
J	2016	Trax	Body	Radio	V	V																		V	V																																	
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																	
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)	V	V																		V	V																																	
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)	V	V																		V	V																																	
J	2016	Trax	Body	Seat Memory Control Module	V																																																				
J	2016	Trax	Body	Front Seat Heating Control Module	V	V																		V	V																																	
J	2016	Trax	Body	Right Side Object Detection Control Module	V																			V	V																																	
J	2016	Trax	Body	Left Side Object Detection Control Module	V																			V	V																																	
J	2016	Trax	Body	Parking Assist Control Module	V																			V	V																																	
J	2016	Trax	Body	Frontview Camera Module	V	V																		V	V																																	
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM	V	V										V	V				V	V		V	V							V													V														
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM		V																		V																																	
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM		V																		V																																	
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM		V																		V																																	
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM	V	V																		V										V	V																					
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case	V	V																		V																																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V	V		V	V							V													V														
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V										V	V																					
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V	V		V	V							V													V														
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V										V	V																					
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case	V	V																		V																																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case	V	V																		V																																	
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V														
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																					
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case	V	V																		V																																	
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V										V	V																					
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case	V	V																		V																																	
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																					
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable	V	V																		V																																	
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control	V	V																		V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V	V		V	V							V													V															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable	V	V																		V																																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable	V	V																		V																																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control	V	V																		V																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module	V	V										V	V				V			V	V							V													V															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600	V	V																		V										V	V																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600	V	V																		V										V	V																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable	V	V																		V																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable	V	V																		V																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control	V	V																		V																																				
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V			V	V							V													V															
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V										V	V																									
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module	V	V																		V	V																																			
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module	V	V																		V										V	V	V																								
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case	V	V																		V																																				
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V																		V																																				
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V										V	V	V																								
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case	V	V																		V																																				
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module	V	V										V	V				V	V		V	V							V													V															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed	V	V																		V										V	V																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed	V	V																		V										V	V	V																								
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable	V	V																		V																																				
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable	V	V																		V																																				
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW	V	V																		V																																				
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																			
K	2004	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																			
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)		V																		V																																				
K	2004	ALL	Chassis	ESC	V	V																		V	V																																			
K	2004	ALL	Chassis	Rear Wheel Steering	V	V																		V	V																																			
K	2004	ALL	Chassis	Tire Pressure Monitor	V	V																																																					
K	2004	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
K	2004	ALL	Chassis	VSES	V	V																		V	V																																			
K	2004	ALL	Body	Amplifier (Bose)	V	V																			V																																			
K	2004	ALL	Body	Body Control Module	V	V																		V	V																																			
K	2004	ALL	Body	CD Changer	V																																																						
K	2004	ALL	Body	Chime	V	V																		V	V																																			
K	2004	ALL	Body	Driver Door Module	V	V																		V	V																																			
K	2004	ALL	Body	Driver Seat Module	V	V																		V	V																																			
K	2004	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
K	2004	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																			
K	2004	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2004	ALL	Body	OnStar	V	V																		V	V																																			
K	2004	ALL	Body	Passenger Door Module	V	V																		V	V																																			
K	2004	ALL	Body	Passenger Presence System																																																							
K	2004	ALL	Body	Radio Base	V	V																			V																																			
K	2004	ALL	Body	Radio Uplevel	V	V																			V																																			
K	2004	ALL	Body	Radio Navigation	V	V																		V																																				
K	2004	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
K	2004	ALL	Body	Rear HVAC	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2004	ALL	Body	Rear Seat Audio	V	V																			V																																			
K	2004	ALL	Body	Rear Seat Entertainment	V																				V																																			
K	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
K	2004	ALL	Body	Vehicle Theft Deterrent	V	V																																																						
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM		V																		V																																			
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM		V																		V																																			
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM		V																		V																																			
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC	V	V																		V																																			
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC	V	V																		V																																			
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC	V	V																		V																																			
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case	V	V																		V																																			
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case	V	V																		V																																			
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case	V	V																		V																																			
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable	V	V																		V																																			
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control	V	V																		V																																			
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable	V	V																		V																																			
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable	V	V																		V																																			
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control	V	V																		V																																			
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module	V	V										V	V				V			V	V							V														V													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable	V	V																		V																																			
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable	V	V																		V																																			
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control	V	V																		V																																			
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V			V	V							V														V													
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V																		V																																			
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V										V	V	V																							
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case	V	V																		V																																			
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed	V	V																		V										V	V	V																							
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable	V	V																		V																																			
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable	V	V																		V																																			
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW	V	V																		V																																					
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																			
K	2005	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																			
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)		V																		V																																				
K	2005	ALL	Chassis	ESC	V	V																		V	V																																			
K	2005	ALL	Chassis	Rear Wheel Steering	V	V																		V	V																																			
K	2005	ALL	Chassis	Tire Pressure Monitor	V	V																																																						
K	2005	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
K	2005	ALL	Chassis	VSES	V	V																		V	V																																			
K	2005	ALL	Body	Amplifier (Bose)	V	V																			V																																			
K	2005	ALL	Body	Body Control Module	V	V																		V	V																																			
K	2005	ALL	Body	CD Changer	V																																																						
K	2005	ALL	Body	Chime	V	V																		V	V																																			
K	2005	ALL	Body	Disc Player and Video Display	V																				V																																			
K	2005	ALL	Body	Driver Door Module	V	V																		V	V																																			
K	2005	ALL	Body	Driver Seat Module	V	V																		V	V																																			
K	2005	ALL	Body	Generator Battery Control Module	V	V																		V	V																																			
K	2005	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																			
K	2005	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
K	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2005	ALL	Body	Passenger Door Module	V	V																		V	V																																			
K	2005	ALL	Body	Passenger Presence System																																																						
K	2005	ALL	Body	Base Radio	V	V																			V																																			
K	2005	ALL	Body	Uplevel Radio	V	V																			V																																			
K	2005	ALL	Body	Navigation Radio	V	V																		V																																			
K	2005	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
K	2005	ALL	Body	Rear HVAC	V	V																			V																																			
K	2005	ALL	Body	Rear Seat Audio	V	V																			V																																			
K	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
K	2005	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
K	2005	ALL	Body	Vehicle Theft Deterrent	V	V																																																					
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM	V	V										V	V				V	V		V	V							V														V													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM		V																		V																																			
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM		V																		V																																			
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM		V																		V																																			
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM	V	V																		V										V	V																							
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC	V	V																		V																																			
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V	V		V	V							V														V													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V										V	V																							
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V	V		V	V							V														V													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V										V	V																							
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC	V	V																		V																																			
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case	V	V																		V																																			
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V										V	V																							
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case	V	V																		V																																			
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module	V	V																		V										V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case	V	V																		V																																						
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V													V															
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable	V	V																		V																																					
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control	V	V																		V																																					
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V	V		V	V							V													V															
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable	V	V																		V																																					
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable	V	V																		V																																					
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control	V	V																		V																																					
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module	V	V										V	V				V			V	V							V													V															
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600	V	V																		V										V	V																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600	V	V																		V										V	V																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable	V	V																		V																																					
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable	V	V																		V																																					
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control	V	V																		V																																					
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V			V	V							V													V															
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V										V	V																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable	V	V																		V																																					
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable	V	V																		V																																					
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module	V	V															V			V																																					
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module	V	V																		V										V	V	V																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display		V																		V	V																																				
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case	V	V																		V																																					
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V															V			V																																					
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V										V	V	V																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display		V																		V	V																																				
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case	V	V																		V																																					
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module	V	V										V	V				V	V		V	V							V													V															
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed	V	V																		V										V	V	V																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed	V	V																		V										V	V																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable	V	V																		V																																					
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable	V	V																		V																																					
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW	V	V																		V	V																																				
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW	V	V																		V																																					
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																				
K	2006	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																				
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)		V																		V																																					
K	2006	ALL	Chassis	ESC	V	V																		V	V																																				
K	2006	ALL	Chassis	Tire Pressure Monitor	V	V																																																						
K	2006	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																					
K	2006	ALL	Chassis	VSES	V	V																		V	V																																				
K	2006	ALL	Body	Amplifier (Bose)	V	V																			V																																				
K	2006	ALL	Body	Body Control Module	V	V																		V	V																																				
K	2006	ALL	Body	CD Changer	V																																																						
K	2006	ALL	Body	Chime	V	V																		V	V																																			
K	2006	ALL	Body	Disc Player and Video Display	V																				V																																				
K	2006	ALL	Body	Driver Door Module	V	V																		V	V																																				
K	2006	ALL	Body	Driver Seat Module	V	V																		V	V																																				
K	2006	ALL	Body	Generator Battery Control Module	V	V																		V	V																																				
K	2006	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																			
K	2006	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
K	2006	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2006	ALL	Body	Passenger Door Module	V	V																		V	V																																			
K	2006	ALL	Body	Passenger Presence System																																																							
K	2006	ALL	Body	Base Radio	V	V																			V																																			
K	2006	ALL	Body	Uplevel Radio	V	V																			V																																			
K	2006	ALL	Body	Navigation Radio	V	V																		V																																			
K	2006	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
K	2006	ALL	Body	Rear HVAC	V	V																			V																																			
K	2006	ALL	Body	Rear Seat Audio	V	V																			V																																			
K	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
K	2006	ALL	Body	Vehicle Theft Deterrent	V	V																																																						
K	2006	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																									
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V																									
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																									
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V													
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V																									
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
K	2007	Avalanche	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2007	Avalanche	Chassis	Trailer Brake Control Module	V	V																			V																																			
K	2007	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2007	Avalanche	Body	Assist Step Controller	V	V																		V	V																																			
K	2007	Avalanche	Body	Body Control Module	V	V																		V	V																																			
K	2007	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2007	Avalanche	Body	Digital Radio Receiver	V	V																			V																																			
K	2007	Avalanche	Body	Driver Door Switch	V	V																		V	V																																			
K	2007	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2007	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2007	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2007	Avalanche	Body	Memory Seat Module	V	V																		V	V																																			
K	2007	Avalanche	Body	Park Assist Module	V	V																		V	V																																			
K	2007	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																			
K	2007	Avalanche	Body	Passenger Presence System	V	V																			V																																			
K	2007	Avalanche	Body	Radio	V	V																		V	V																																			
K	2007	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																			
K	2007	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2007	Avalanche	Body	Rollover Sensor	V	V																			V																																			
K	2007	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2007	Avalanche	Body	Theft Deterrent Module	V	V																			V																																			
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V																							
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V																							
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V											V	V																							
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V																				V													
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V											V	V																							
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V													
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V											V	V																							
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
K	2007	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2007	Suburban	Chassis	Trailer Brake Control Module	V	V																			V																																		
K	2007	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2007	Suburban	Body	Assist Step Controller	V	V																		V	V																																		
K	2007	Suburban	Body	Body Control Module	V	V																		V	V																																		
K	2007	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2007	Suburban	Body	Digital Radio Receiver	V	V																			V																																		
K	2007	Suburban	Body	Driver Door Switch	V	V																		V	V																																		
K	2007	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2007	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2007	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2007	Suburban	Body	Lift Gate Module	V	V																		V	V																																		
K	2007	Suburban	Body	Memory Seat Module	V	V																		V	V																																		
K	2007	Suburban	Body	Park Assist Module	V	V																		V	V																																		
K	2007	Suburban	Body	Passenger Door Switch	V	V																		V	V																																		
K	2007	Suburban	Body	Passenger Presence System	V	V																			V																																		
K	2007	Suburban	Body	Radio	V	V																		V	V																																		
K	2007	Suburban	Body	Rear Heated Seat Module	V	V																			V																																		
K	2007	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2007	Suburban	Body	Rollover Sensor	V	V																			V																																		
K	2007	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2007	Suburban	Body	Theft Deterrent Module	V	V																			V																																		
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V													
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V													
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V											V	V																							
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V																							
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V																									
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																								
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																								
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V													
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																							
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V													
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V							V							V			V	V																																		
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																		
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module	V	V																		V	V																																		
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																							
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
K	2007	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2007	Silverado	Chassis	Trailer Brake Control Module	V	V																			V																																		
K	2007	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2007	Silverado	Body	Body Control Module	V	V																		V	V																																		
K	2007	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2007	Silverado	Body	Digital Radio Receiver	V	V																			V																																		
K	2007	Silverado	Body	Driver Door Switch	V	V																		V	V																																		
K	2007	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2007	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2007	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2007	Silverado	Body	Memory Seat Module	V	V																		V	V																																		
K	2007	Silverado	Body	Park Assist Module	V	V																		V	V																																		
K	2007	Silverado	Body	Passenger Door Switch	V	V																		V	V																																		
K	2007	Silverado	Body	Passenger Presence System	V	V																			V																																		
K	2007	Silverado	Body	Radio	V	V																		V	V																																		
K	2007	Silverado	Body	Rear Heated Seat Module	V	V																			V																																		
K	2007	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2007	Silverado	Body	Rollover Sensor	V	V																			V																																		
K	2007	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2007	Silverado	Body	Theft Deterrent Module	V	V																			V																																		
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V													
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																		
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																								
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																				
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																									
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
K	2007	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2007	Tahoe	Chassis	Trailer Brake Control Module	V	V																			V																																			
K	2007	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2007	Tahoe	Body	Assist Step Controller	V	V																		V	V																																			
K	2007	Tahoe	Body	Body Control Module	V	V																		V	V																																			
K	2007	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2007	Tahoe	Body	Digital Radio Receiver	V	V																			V																																			
K	2007	Tahoe	Body	Driver Door Switch	V	V																		V	V																																			
K	2007	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2007	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2007	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2007	Tahoe	Body	Lift Gate Module	V	V																		V	V																																			
K	2007	Tahoe	Body	Memory Seat Module	V	V																		V	V																																			
K	2007	Tahoe	Body	Park Assist Module	V	V																		V	V																																			
K	2007	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																			
K	2007	Tahoe	Body	Passenger Presence System	V	V																			V																																			
K	2007	Tahoe	Body	Radio	V	V																		V	V																																			
K	2007	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																			
K	2007	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2007	Tahoe	Body	Rollover Sensor	V	V																			V																																			
K	2007	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2007	Tahoe	Body	Theft Deterrent Module	V	V																			V																																			
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																									
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V																									
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																									
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V													
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V																									
K	2008	Avalanche	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2008	Avalanche	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2008	Avalanche	Chassis	Trailer Brake Control Module	V	V																			V																																			
K	2008	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2008	Avalanche	Body	Assist Step Controller	V	V																		V	V																																			
K	2008	Avalanche	Body	Body Control Module	V	V																		V	V																																			
K	2008	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2008	Avalanche	Body	Digital Radio Receiver	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2008	Avalanche	Body	Driver Door Switch	V	V																		V	V																																			
K	2008	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2008	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2008	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2008	Avalanche	Body	Memory Seat Module	V	V																		V	V																																			
K	2008	Avalanche	Body	Park Assist Module	V	V																		V	V																																			
K	2008	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																			
K	2008	Avalanche	Body	Passenger Presence System	V	V																			V																																			
K	2008	Avalanche	Body	Radio	V	V																		V	V																																			
K	2008	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																			
K	2008	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2008	Avalanche	Body	Rollover Sensor	V	V																			V																																			
K	2008	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2008	Avalanche	Body	Theft Deterrent Module	V	V																			V																																			
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V																							
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V																							
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V											V	V																							
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V																					V													
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V											V	V	V																							
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V													
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V											V	V																							
K	2008	Suburban	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																			
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
K	2008	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2008	Suburban	Chassis	Trailer Brake Control Module	V	V																			V																																			
K	2008	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2008	Suburban	Body	Assist Step Controller	V	V																		V	V																																			
K	2008	Suburban	Body	Body Control Module	V	V																		V	V																																			
K	2008	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2008	Suburban	Body	Digital Radio Receiver	V	V																			V																																			
K	2008	Suburban	Body	Driver Door Switch	V	V																		V	V																																			
K	2008	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2008	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2008	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2008	Suburban	Body	Lift Gate Module	V	V																		V	V																																			
K	2008	Suburban	Body	Memory Seat Module	V	V																		V	V																																			
K	2008	Suburban	Body	Park Assist Module	V	V																		V	V																																			
K	2008	Suburban	Body	Passenger Door Switch	V	V																		V	V																																			
K	2008	Suburban	Body	Passenger Presence System	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2008	Suburban	Body	Radio	V	V																		V	V																																			
K	2008	Suburban	Body	Rear Heated Seat Module	V	V																			V																																			
K	2008	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2008	Suburban	Body	Rollover Sensor	V	V																			V																																			
K	2008	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2008	Suburban	Body	Theft Deterrent Module	V	V																			V																																			
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V							V														V													
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																	V											V	V																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V					V			V	V	V			V	V		V	V							V														V													
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																	V											V	V																								
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V							V														V													
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																	V											V	V																								
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V							V														V													
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																	V											V	V																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V							V														V													
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																	V											V	V																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V							V														V													
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																	V											V	V																								
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V			V			V	V	V			V	V		V	V							V														V													
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																	V											V	V	V																							
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V			V			V	V	V	V		V	V		V	V							V														V													
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																	V											V	V																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V							V						V			V	V																																			
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																	V	V																																			
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module	V	V																	V	V																																			
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																	V											V	V	V																							
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																	V	V																																			
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																	V	V																																			
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW	V	V																	V	V																																			
K	2008	Silverado	Chassis	Electronic Suspension Control	V	V																	V	V																																			
K	2008	Silverado	Chassis	Trailer Brake Control Module	V	V																		V																																			
K	2008	Silverado	Body	Amplifier (Bose)	V	V																	V	V																																			
K	2008	Silverado	Body	Body Control Module	V	V																	V	V																																			
K	2008	Silverado	Body	Body Control Module (aux.)	V	V																	V	V																																			
K	2008	Silverado	Body	Digital Radio Receiver	V	V																		V																																			
K	2008	Silverado	Body	Driver Door Switch	V	V																	V	V																																			
K	2008	Silverado	Body	HVAC Control Module Auto	V	V																	V	V																																			
K	2008	Silverado	Body	HVAC Control Module Manual	V	V																	V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2008	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																					
K	2008	Silverado	Body	Memory Seat Module	V	V																		V	V																																					
K	2008	Silverado	Body	Park Assist Module	V	V																		V	V																																					
K	2008	Silverado	Body	Passenger Door Switch	V	V																		V	V																																					
K	2008	Silverado	Body	Passenger Presence System	V	V																			V																																					
K	2008	Silverado	Body	Radio	V	V																		V	V																																					
K	2008	Silverado	Body	Rear Heated Seat Module	V	V																			V																																					
K	2008	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																					
K	2008	Silverado	Body	Rollover Sensor	V	V																			V																																					
K	2008	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																					
K	2008	Silverado	Body	Theft Deterrent Module	V	V																			V																																					
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V						V														V																
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																											
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																					
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V																
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																											
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																					
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																					
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V																
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																											
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																					
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																					
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module	V	V																		V	V																																					
K	2008	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
K	2008	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																					
K	2008	Tahoe	Chassis	Trailer Brake Control Module	V	V																			V																																					
K	2008	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																					
K	2008	Tahoe	Body	Assist Step Controller	V	V																		V	V																																					
K	2008	Tahoe	Body	Body Control Module	V	V																		V	V																																					
K	2008	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																					
K	2008	Tahoe	Body	Digital Radio Receiver	V	V																			V																																					
K	2008	Tahoe	Body	Driver Door Switch	V	V																		V	V																																					
K	2008	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																					
K	2008	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																					
K	2008	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																					
K	2008	Tahoe	Body	Lift Gate Module	V	V																		V	V																																					
K	2008	Tahoe	Body	Memory Seat Module	V	V																		V	V																																					
K	2008	Tahoe	Body	Park Assist Module	V	V																		V	V																																					
K	2008	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																					
K	2008	Tahoe	Body	Passenger Presence System	V	V																			V																																					
K	2008	Tahoe	Body	Radio	V	V																		V	V																																					
K	2008	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																					
K	2008	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																					
K	2008	Tahoe	Body	Rollover Sensor	V	V																			V																																					
K	2008	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																					
K	2008	Tahoe	Body	Theft Deterrent Module	V	V																			V																																					
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V						V														V																
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																					
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																					
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																					
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																							
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																						
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																	V										V		V																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module	V	V																																																					
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module	V	V																		V																																			
K	2008	Tahoe Hybrid	Body	Lift Gate Module	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Passenger Door Switch	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module	V	V																		V																																			
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Body Control Module	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver	V	V																		V																																			
K	2008	Tahoe Hybrid	Body	Driver Door Switch	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	HVAC Control Module	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Lift Gate Module	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Memory Seat Module	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Park Assist Module	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Passenger Door Switch	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Passenger Presence System	V	V																		V																																			
K	2008	Tahoe Hybrid	Body	Radio	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module	V	V																		V																																			
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Rollover Sensor	V	V																		V																																			
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module	V	V																	V	V																																			
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint	V	V																		V																																			
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module	V	V																		V																																			
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V	V	V							V													V														
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																	V	V																																			
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																	V	V																																			
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed	V	V																	V										V	V																							
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed	V	V																	V										V	V	V																						
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V	V	V							V													V														
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																	V	V																																			
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																	V	V																																			
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed	V	V																	V										V	V																							
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed	V	V																	V										V	V	V																						
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V	V	V							V													V														
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																	V	V																																			
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																	V	V																																			
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed	V	V																	V										V	V																							
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed	V	V																	V										V	V	V																						
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V	V	V							V													V														
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																	V	V																																			
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																	V	V																																			
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																	V										V	V	V																						
K	2009	Avalanche	Chassis	Electronic Brake Control Module	V	V																	V	V																																			
K	2009	Avalanche	Chassis	Electronic Suspension Control	V	V																	V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2009	Avalanche	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
K	2009	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2009	Avalanche	Body	Assist Step Controller	V	V																		V	V																																			
K	2009	Avalanche	Body	Body Control Module	V	V																		V	V																																			
K	2009	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2009	Avalanche	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2009	Avalanche	Body	Driver Door Switch	V	V																		V	V																																			
K	2009	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2009	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2009	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2009	Avalanche	Body	Memory Seat Module	V	V																		V	V																																			
K	2009	Avalanche	Body	Park Assist Module	V	V																		V	V																																			
K	2009	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																			
K	2009	Avalanche	Body	Passenger Presence System	V	V																			V																																			
K	2009	Avalanche	Body	Radio	V	V																		V	V																																			
K	2009	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																			
K	2009	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2009	Avalanche	Body	Rollover Sensor	V	V																			V																																			
K	2009	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2009	Avalanche	Body	Theft Deterrent Module	V	V																			V																																			
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																									
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V																									
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																			
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																			
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																		V	V																																			
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																			
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES	V	V																		V	V																																			
K	2009	Cheyenne	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
K	2009	Cheyenne	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2009	Cheyenne	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2009	Cheyenne	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2009	Cheyenne	Body	Driver Door Switch	V	V																		V	V																																			
K	2009	Cheyenne	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2009	Cheyenne	Body	Park Assist Module	V	V																		V	V																																			
K	2009	Cheyenne	Body	Passenger Door Switch	V	V																		V	V																																			
K	2009	Cheyenne	Body	Passenger Presence System	V	V																			V																																			
K	2009	Cheyenne	Body	Rear Heated Seat Module	V	V																			V																																			
K	2009	Cheyenne	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2009	Cheyenne	Body	Rollover Sensor	V	V																			V																																			
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2009	Cheyenne	Body	Theft Deterrent Module	V	V																			V																																			
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																			V														
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V																			V														
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Suburban	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																		
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
K	2009	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2009	Suburban	Chassis	Trailer Brake Control Module	V	V																		V	V																																		
K	2009	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2009	Suburban	Body	Assist Step Controller	V	V																		V	V																																		
K	2009	Suburban	Body	Body Control Module	V	V																		V	V																																		
K	2009	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2009	Suburban	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2009	Suburban	Body	Driver Door Switch	V	V																		V	V																																		
K	2009	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2009	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2009	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2009	Suburban	Body	Left Side Object Detection Module	V	V																		V	V																																		
K	2009	Suburban	Body	Lift Gate Module	V	V																		V	V																																		
K	2009	Suburban	Body	Memory Seat Module	V	V																		V	V																																		
K	2009	Suburban	Body	Park Assist Module	V	V																		V	V																																		
K	2009	Suburban	Body	Passenger Door Switch	V	V																		V	V																																		
K	2009	Suburban	Body	Passenger Presence System	V	V																			V																																		
K	2009	Suburban	Body	Radio	V	V																		V	V																																		
K	2009	Suburban	Body	Rear Heated Seat Module	V	V																			V																																		
K	2009	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2009	Suburban	Body	Right Side Object Detection Module	V	V																			V																																		
K	2009	Suburban	Body	Rollover Sensor	V	V																			V																																		
K	2009	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2009	Suburban	Body	Theft Deterrent Module	V	V																			V																																		
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed	V	V																		V										V	V																							
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed	V	V																		V										V	V	V																						
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																						
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed	V	V																		V										V	V																							
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed	V	V																		V										V	V	V																						
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V	V																						
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V													
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V	V																						
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V													
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V													
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																						
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																						
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																		
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																		
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module	V	V																		V	V																																		
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																						
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES	V	V																		V	V																																		
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																		
K	2009	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2009	Silverado	Chassis	Trailer Brake Control Module	V	V																		V	V																																		
K	2009	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2009	Silverado	Body	Body Control Module	V	V																		V	V																																		
K	2009	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2009	Silverado	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2009	Silverado	Body	Driver Door Switch	V	V																		V	V																																		
K	2009	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2009	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2009	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2009	Silverado	Body	Memory Seat Module	V	V																		V	V																																		
K	2009	Silverado	Body	Park Assist Module	V	V																		V	V																																		
K	2009	Silverado	Body	Passenger Door Switch	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2009	Silverado	Body	Passenger Presence System	V	V																			V																																			
K	2009	Silverado	Body	Radio	V	V																		V	V																																		
K	2009	Silverado	Body	Rear Heated Seat Module	V	V																			V																																			
K	2009	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2009	Silverado	Body	Rollover Sensor	V	V																			V																																			
K	2009	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2009	Silverado	Body	Theft Deterrent Module	V	V																			V																																			
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																					
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																					
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																			
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module	V	V																																																					
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
K	2009	Silverado Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	Body Control Module	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	Digital Radio Receiver	V	V																			V																																			
K	2009	Silverado Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	Memory Seat Module	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	Park Assist Module	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	Passenger Presence System	V	V																			V																																			
K	2009	Silverado Hybrid	Body	Radio	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	Rollover Sensor	V	V																			V																																			
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2009	Silverado Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																			
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module	V	V																		V	V																																			
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed	V	V																		V										V	V																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																								
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed	V	V																		V										V	V																								
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																		
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
K	2009	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2009	Tahoe	Chassis	Trailer Brake Control Module	V	V																		V	V																																		
K	2009	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2009	Tahoe	Body	Assist Step Controller	V	V																		V	V																																		
K	2009	Tahoe	Body	Body Control Module	V	V																		V	V																																		
K	2009	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2009	Tahoe	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2009	Tahoe	Body	Driver Door Switch	V	V																		V	V																																		
K	2009	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2009	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2009	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2009	Tahoe	Body	Left Side Object Detection Module	V	V																		V	V																																		
K	2009	Tahoe	Body	Lift Gate Module	V	V																		V	V																																		
K	2009	Tahoe	Body	Memory Seat Module	V	V																		V	V																																		
K	2009	Tahoe	Body	Park Assist Module	V	V																		V	V																																		
K	2009	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																		
K	2009	Tahoe	Body	Passenger Presence System	V	V																			V																																		
K	2009	Tahoe	Body	Radio	V	V																		V	V																																		
K	2009	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																		
K	2009	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2009	Tahoe	Body	Right Side Object Detection Module	V	V																			V																																		
K	2009	Tahoe	Body	Rollover Sensor	V	V																			V																																		
K	2009	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2009	Tahoe	Body	Theft Deterrent Module	V	V																			V																																		
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																		
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																		
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																		
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																			
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																			
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																		
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module	V	V																																																				
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module	V	V																		V	V																																		
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2009	Tahoe Hybrid	Body	Body Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver	V	V																			V																																			
K	2009	Tahoe Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
K	2009	Tahoe Hybrid	Body	Heated Seat Module	V	V																			V																																			
K	2009	Tahoe Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2009	Tahoe Hybrid	Body	Park Assist Module	V	V																		V	V																																			
K	2009	Tahoe Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
K	2009	Tahoe Hybrid	Body	Passenger Presence System	V	V																			V																																			
K	2009	Tahoe Hybrid	Body	Radio	V	V																		V	V																																			
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module	V	V																			V																																			
K	2009	Tahoe Hybrid	Body	Rollover Sensor	V	V																			V																																			
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																			
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																			
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V														
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed	V	V																		V	V																																			
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed	V	V																		V	V																																			
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
K	2010	Avalanche	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2010	Avalanche	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2010	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2010	Avalanche	Body	Assist Step Controller	V	V																		V	V																																			
K	2010	Avalanche	Body	Body Control Module	V	V																		V	V																																			
K	2010	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2010	Avalanche	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2010	Avalanche	Body	Driver Door Switch	V	V																		V	V																																			
K	2010	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2010	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2010	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2010	Avalanche	Body	Memory Seat Module	V	V																		V	V																																			
K	2010	Avalanche	Body	Park Assist Module	V	V																			V																																			
K	2010	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																			
K	2010	Avalanche	Body	Passenger Presence System	V	V																			V																																			
K	2010	Avalanche	Body	Radio	V	V																		V	V																																			
K	2010	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																			
K	2010	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2010	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2010	Avalanche	Body	Theft Deterrent Module	V	V																			V																																			
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																				
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																			
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																						
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																		
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES	V	V																		V	V																																		
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																		
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES	V	V																		V	V																																		
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2010	Cheyenne	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2010	Cheyenne	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2010	Cheyenne	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2010	Cheyenne	Body	Driver Door Switch	V	V																		V	V																																		
K	2010	Cheyenne	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2010	Cheyenne	Body	Park Assist Module	V	V																			V																																		
K	2010	Cheyenne	Body	Passenger Door Switch	V	V																		V	V																																		
K	2010	Cheyenne	Body	Passenger Presence System	V	V																			V																																		
K	2010	Cheyenne	Body	Rear Heated Seat Module	V	V																			V																																		
K	2010	Cheyenne	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2010	Cheyenne	Body	Theft Deterrent Module	V	V																			V																																		
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V		V	V			V	V																				V													
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																						
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V		V				V		V	V	V	V		V	V			V	V																				V													
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V	V																						
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																		
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																						
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V														V													
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																		
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																						
K	2010	Suburban	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																		
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
K	2010	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2010	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2010	Suburban	Body	Assist Step Controller	V	V																		V	V																																		
K	2010	Suburban	Body	Body Control Module	V	V																		V	V																																		
K	2010	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2010	Suburban	Body	Digital Radio Receiver	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2010	Suburban	Body	Driver Door Switch	V	V																		V	V																																				
K	2010	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																				
K	2010	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																				
K	2010	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																				
K	2010	Suburban	Body	Left Side Object Detection Module	V	V																		V	V																																				
K	2010	Suburban	Body	Lift Gate Module	V	V																		V	V																																				
K	2010	Suburban	Body	Memory Seat Module	V	V																		V	V																																				
K	2010	Suburban	Body	Park Assist Module	V	V																			V																																				
K	2010	Suburban	Body	Passenger Door Switch	V	V																		V	V																																				
K	2010	Suburban	Body	Passenger Presence System	V	V																			V																																				
K	2010	Suburban	Body	Radio	V	V																		V	V																																				
K	2010	Suburban	Body	Rear Heated Seat Module	V	V																			V																																				
K	2010	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																				
K	2010	Suburban	Body	Right Side Object Detection Module	V	V																			V																																				
K	2010	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																				
K	2010	Suburban	Body	Theft Deterrent Module	V	V																			V																																				
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V	V	V						V			V	V	V	V		V	V		V	V							V														V														
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V							V														V														
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V														V														
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																									
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V														
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V														
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																								
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V														
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																								
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V														V														
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V														V														
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V														V														
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																				
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																				
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module	V	V																		V	V																																				
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																								
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																				
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																				
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																			
K	2010	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																			
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																			
K	2010	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2010	Silverado	Body	Body Control Module	V	V																		V	V																																			
K	2010	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2010	Silverado	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2010	Silverado	Body	Driver Door Switch	V	V																		V	V																																			
K	2010	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2010	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2010	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2010	Silverado	Body	Memory Seat Module	V	V																		V	V																																			
K	2010	Silverado	Body	Park Assist Module	V	V																			V																																			
K	2010	Silverado	Body	Passenger Door Switch	V	V																		V	V																																			
K	2010	Silverado	Body	Passenger Presence System	V	V																			V																																			
K	2010	Silverado	Body	Radio	V	V																		V	V																																			
K	2010	Silverado	Body	Rear Heated Seat Module	V	V																			V																																			
K	2010	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2010	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2010	Silverado	Body	Theft Deterrent Module	V	V																			V																																			
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V															
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																					
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																					
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V											V		V																							
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																			
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module	V	V																																																					
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
K	2010	Silverado Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2010	Silverado Hybrid	Body	Body Control Module	V	V																		V	V																																			
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2010	Silverado Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2010	Silverado Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
K	2010	Silverado Hybrid	Body	Heated Seat Module	V	V																			V																																			
K	2010	Silverado Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2010	Silverado Hybrid	Body	Park Assist Module	V	V																			V																																			
K	2010	Silverado Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
K	2010	Silverado Hybrid	Body	Passenger Presence System	V	V																			V																																			
K	2010	Silverado Hybrid	Body	Radio	V	V																		V	V																																			
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2010	Silverado Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																						
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																						
K	2010	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
K	2010	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2010	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2010	Tahoe	Body	Assist Step Controller	V	V																		V	V																																		
K	2010	Tahoe	Body	Body Control Module	V	V																		V	V																																		
K	2010	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2010	Tahoe	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2010	Tahoe	Body	Driver Door Switch	V	V																		V	V																																		
K	2010	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2010	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2010	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2010	Tahoe	Body	Left Side Object Detection Module	V	V																		V	V																																		
K	2010	Tahoe	Body	Lift Gate Module	V	V																		V	V																																		
K	2010	Tahoe	Body	Memory Seat Module	V	V																		V	V																																		
K	2010	Tahoe	Body	Park Assist Module	V	V																			V																																		
K	2010	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																		
K	2010	Tahoe	Body	Passenger Presence System	V	V																			V																																		
K	2010	Tahoe	Body	Radio	V	V																		V	V																																		
K	2010	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																		
K	2010	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2010	Tahoe	Body	Right Side Object Detection Module	V	V																			V																																		
K	2010	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2010	Tahoe	Body	Theft Deterrent Module	V	V																			V																																		
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																		
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																		
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																		
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																				
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																				
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																						
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module	V	V																																																				
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Body	Body Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Body	Driver Door Switch	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Body	Heated Seat Module	V	V																			V																																		
K	2010	Tahoe Hybrid	Body	HVAC Control Module	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Body	Lift Gate Module	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Body	Park Assist Module	V	V																			V																																		
K	2010	Tahoe Hybrid	Body	Passenger Door Switch	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Body	Passenger Presence System	V	V																			V																																		
K	2010	Tahoe Hybrid	Body	Radio	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module	V	V																			V																																		
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module	V	V																			V																																		
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																		
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module	V	V																			V																																		
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V	V																					
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																					
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2011	Avalanche	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
K	2011	Avalanche	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2011	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2011	Avalanche	Body	Assist Step Controller	V	V																		V	V																																		
K	2011	Avalanche	Body	Body Control Module	V	V																		V	V																																		
K	2011	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2011	Avalanche	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2011	Avalanche	Body	Driver Door Switch	V	V																		V	V																																		
K	2011	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2011	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2011	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2011	Avalanche	Body	Memory Seat Module	V	V																		V	V																																		
K	2011	Avalanche	Body	Park Assist Module	V	V																			V																																		
K	2011	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																		
K	2011	Avalanche	Body	Passenger Presence System	V	V																			V																																		
K	2011	Avalanche	Body	Radio	V	V																		V	V																																		
K	2011	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																		
K	2011	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2011	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2011	Avalanche	Body	Theft Deterrent Module	V	V																			V																																		
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																						
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																		
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V	V																						
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES	V	V																		V	V																																		
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																		
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES	V	V																		V	V																																		
K	2011	Cheyenne	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2011	Cheyenne	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2011	Cheyenne	Body	Body Control Module	V	V																		V	V																																		
K	2011	Cheyenne	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2011	Cheyenne	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2011	Cheyenne	Body	Driver Door Switch	V	V																		V	V																																		
K	2011	Cheyenne	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2011	Cheyenne	Body	Park Assist Module	V	V																			V																																		
K	2011	Cheyenne	Body	Passenger Door Switch	V	V																		V	V																																		
K	2011	Cheyenne	Body	Passenger Presence System	V	V																			V																																		
K	2011	Cheyenne	Body	Rear Heated Seat Module	V	V																			V																																		
K	2011	Cheyenne	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2011	Cheyenne	Body	Theft Deterrent Module	V	V																			V																																		
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																				V														
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																						
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																				V														
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V	V																						
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																		
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																						
K	2011	Suburban	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																		
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
K	2011	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2011	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2011	Suburban	Body	Assist Step Controller	V	V																		V	V																																		
K	2011	Suburban	Body	Body Control Module	V	V																		V	V																																		
K	2011	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2011	Suburban	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2011	Suburban	Body	Driver Door Switch	V	V																		V	V																																		
K	2011	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2011	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2011	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2011	Suburban	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2011	Suburban	Body	Lift Gate Module	V	V																		V	V																																			
K	2011	Suburban	Body	Memory Seat Module	V	V																		V	V																																			
K	2011	Suburban	Body	Park Assist Module	V	V																			V																																			
K	2011	Suburban	Body	Passenger Door Switch	V	V																		V	V																																			
K	2011	Suburban	Body	Passenger Presence System	V	V																			V																																			
K	2011	Suburban	Body	Radio	V	V																		V	V																																			
K	2011	Suburban	Body	Rear Heated Seat Module	V	V																			V																																			
K	2011	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2011	Suburban	Body	Right Side Object Detection Module	V	V																			V																																			
K	2011	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2011	Suburban	Body	Theft Deterrent Module	V	V																			V																																			
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V	V	V						V			V	V	V		V	V			V	V						V													V															
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V	V	V						V			V	V	V		V	V			V	V						V													V															
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V						V													V															
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																									
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V															
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V															
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V															
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic	V	V			V				V		V	V	V	V	V		V	V		V	V						V													V															
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual	V	V			V				V		V	V	V	V	V		V	V		V	V						V													V															
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V						V													V															
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V								V						V			V	V																																			
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module		V													V					V	V																																			
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module	V	V																		V										V	V	V																							
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																			
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																			
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module	V	V																		V	V																																			
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																							
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																			
K	2011	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																			
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																			
K	2011	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2011	Silverado	Body	Body Control Module	V	V																		V	V																																			
K	2011	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2011	Silverado	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2011	Silverado	Body	Driver Door Switch	V	V																		V	V																																			
K	2011	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2011	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2011	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2011	Silverado	Body	Memory Seat Module	V	V																		V	V																																			
K	2011	Silverado	Body	Park Assist Module	V	V																			V																																			
K	2011	Silverado	Body	Passenger Door Switch	V	V																		V	V																																			
K	2011	Silverado	Body	Passenger Presence System	V	V																			V																																			
K	2011	Silverado	Body	Radio	V	V																		V	V																																			
K	2011	Silverado	Body	Rear Heated Seat Module	V	V																			V																																			
K	2011	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2011	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2011	Silverado	Body	Theft Deterrent Module	V	V																			V																																			
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																				
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																				
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V											V		V																							
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																			
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module	V	V																																																					
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
K	2011	Silverado Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2011	Silverado Hybrid	Body	Body Control Module	V	V																		V	V																																			
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2011	Silverado Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2011	Silverado Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
K	2011	Silverado Hybrid	Body	Heated Seat Module	V	V																			V																																			
K	2011	Silverado Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2011	Silverado Hybrid	Body	Park Assist Module	V	V																			V																																			
K	2011	Silverado Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
K	2011	Silverado Hybrid	Body	Passenger Presence System	V	V																			V																																			
K	2011	Silverado Hybrid	Body	Radio	V	V																		V	V																																			
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2011	Silverado Hybrid	Body	Theft Deterrent Module	V	V																			V																																				
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																			
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																			
K	2011	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2011	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2011	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2011	Tahoe	Body	Assist Step Controller	V	V																		V	V																																			
K	2011	Tahoe	Body	Body Control Module	V	V																		V	V																																			
K	2011	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2011	Tahoe	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2011	Tahoe	Body	Driver Door Switch	V	V																		V	V																																			
K	2011	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2011	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2011	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2011	Tahoe	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2011	Tahoe	Body	Lift Gate Module	V	V																		V	V																																			
K	2011	Tahoe	Body	Memory Seat Module	V	V																		V	V																																			
K	2011	Tahoe	Body	Park Assist Module	V	V																			V																																			
K	2011	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																			
K	2011	Tahoe	Body	Passenger Presence System	V	V																			V																																			
K	2011	Tahoe	Body	Radio	V	V																		V	V																																			
K	2011	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																			
K	2011	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2011	Tahoe	Body	Right Side Object Detection Module	V	V																			V																																			
K	2011	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2011	Tahoe	Body	Theft Deterrent Module	V	V																			V																																			
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																				
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																				
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																			
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module	V	V																																																					
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2011	Tahoe Hybrid	Body	Body Control Module	V	V																		V	V																																			
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2011	Tahoe Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
K	2011	Tahoe Hybrid	Body	Heated Seat Module	V	V																			V																																			
K	2011	Tahoe Hybrid	Body	HVAC Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																		
K	2011	Tahoe Hybrid	Body	Lift Gate Module	V	V																		V	V																																		
K	2011	Tahoe Hybrid	Body	Park Assist Module	V	V																			V																																		
K	2011	Tahoe Hybrid	Body	Passenger Door Switch	V	V																		V	V																																		
K	2011	Tahoe Hybrid	Body	Passenger Presence System	V	V																			V																																		
K	2011	Tahoe Hybrid	Body	Radio	V	V																		V	V																																		
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module	V	V																			V																																		
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module	V	V																			V																																		
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																		
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module	V	V																			V																																		
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																						
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																						
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2012	Avalanche	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
K	2012	Avalanche	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2012	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2012	Avalanche	Body	Assist Step Controller	V	V																		V	V																																		
K	2012	Avalanche	Body	Body Control Module	V	V																		V	V																																		
K	2012	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2012	Avalanche	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2012	Avalanche	Body	Driver Door Switch	V	V																		V	V																																		
K	2012	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2012	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2012	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2012	Avalanche	Body	Memory Seat Module	V	V																		V	V																																		
K	2012	Avalanche	Body	Navigation Radio	V	V																		V	V																																		
K	2012	Avalanche	Body	Park Assist Module	V	V																			V																																		
K	2012	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																		
K	2012	Avalanche	Body	Passenger Presence System	V	V																			V																																		
K	2012	Avalanche	Body	Radio	V	V																		V	V																																		
K	2012	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																		
K	2012	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2012	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2012	Avalanche	Body	Theft Deterrent Module	V	V																			V																																		
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																						
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																		
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																		
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES	V	V																		V	V																																		
K	2012	Cheyenne	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2012	Cheyenne	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2012	Cheyenne	Body	Body Control Module	V	V																		V	V																																		
K	2012	Cheyenne	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2012	Cheyenne	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2012	Cheyenne	Body	Driver Door Switch	V	V																		V	V																																		
K	2012	Cheyenne	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2012	Cheyenne	Body	Park Assist Module	V	V																			V																																		
K	2012	Cheyenne	Body	Passenger Door Switch	V	V																		V	V																																		
K	2012	Cheyenne	Body	Passenger Presence System	V	V																			V																																		
K	2012	Cheyenne	Body	Rear Heated Seat Module	V	V																			V																																		
K	2012	Cheyenne	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2012	Cheyenne	Body	Theft Deterrent Module	V	V																			V																																		
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																				V													
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																		
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
K	2012	Suburban	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																		
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
K	2012	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2012	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2012	Suburban	Body	Assist Step Controller	V	V																		V	V																																		
K	2012	Suburban	Body	Body Control Module	V	V																		V	V																																		
K	2012	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2012	Suburban	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2012	Suburban	Body	Driver Door Switch	V	V																		V	V																																		
K	2012	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2012	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2012	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2012	Suburban	Body	Left Side Object Detection Module	V	V																		V	V																																				
K	2012	Suburban	Body	Lift Gate Module	V	V																		V	V																																				
K	2012	Suburban	Body	Memory Seat Module	V	V																		V	V																																				
K	2012	Suburban	Body	Navigation Radio	V	V																		V	V																																				
K	2012	Suburban	Body	Park Assist Module	V	V																			V																																				
K	2012	Suburban	Body	Passenger Door Switch	V	V																		V	V																																				
K	2012	Suburban	Body	Passenger Presence System	V	V																			V																																				
K	2012	Suburban	Body	Radio	V	V																		V	V																																				
K	2012	Suburban	Body	Rear Heated Seat Module	V	V																			V																																				
K	2012	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																				
K	2012	Suburban	Body	Right Side Object Detection Module	V	V																			V																																				
K	2012	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																				
K	2012	Suburban	Body	Theft Deterrent Module	V	V																			V																																				
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V	V	V						V			V	V	V		V	V			V	V						V														V															
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V	V	V						V			V	V	V		V	V			V	V						V														V															
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V															
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V															
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V															
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																								
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic	V	V			V				V		V	V	V	V	V		V	V		V	V						V														V															
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V															
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V															
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V								V						V			V	V																																				
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module		V													V					V	V																																				
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module	V	V																		V										V	V	V																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																				
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																				
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module	V	V																		V	V																																				
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																								
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																				
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																				
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES	V	V																		V	V																																				
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2012	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																				
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																			
K	2012	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2012	Silverado	Body	Body Control Module	V	V																		V	V																																			
K	2012	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2012	Silverado	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2012	Silverado	Body	Driver Door Switch	V	V																		V	V																																			
K	2012	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2012	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2012	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2012	Silverado	Body	Memory Seat Module	V	V																		V	V																																			
K	2012	Silverado	Body	Navigation Radio	V	V																		V	V																																			
K	2012	Silverado	Body	Park Assist Module	V	V																			V																																			
K	2012	Silverado	Body	Passenger Door Switch	V	V																		V	V																																			
K	2012	Silverado	Body	Passenger Presence System	V	V																			V																																			
K	2012	Silverado	Body	Radio	V	V																		V	V																																			
K	2012	Silverado	Body	Rear Heated Seat Module	V	V																			V																																			
K	2012	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2012	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2012	Silverado	Body	Theft Deterrent Module	V	V																			V																																			
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V														
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																				
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																				
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																				
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																					
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																					
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																			
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module	V	V																																																					
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
K	2012	Silverado Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	Body Control Module	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	Heated Seat Module	V	V																			V																																			
K	2012	Silverado Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	Navigation Radio	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	Park Assist Module	V	V																			V																																			
K	2012	Silverado Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	Passenger Presence System	V	V																			V																																			
K	2012	Silverado Hybrid	Body	Radio	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2012	Silverado Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2012	Tahoe	Chassis	EBCM with Trailer Brake	V	V																		V	V																																		
K	2012	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2012	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2012	Tahoe	Body	Assist Step Controller	V	V																		V	V																																		
K	2012	Tahoe	Body	Body Control Module	V	V																		V	V																																		
K	2012	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2012	Tahoe	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2012	Tahoe	Body	Driver Door Switch	V	V																		V	V																																		
K	2012	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2012	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2012	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2012	Tahoe	Body	Left Side Object Detection Module	V	V																		V	V																																		
K	2012	Tahoe	Body	Lift Gate Module	V	V																		V	V																																		
K	2012	Tahoe	Body	Memory Seat Module	V	V																		V	V																																		
K	2012	Tahoe	Body	Navigation Radio	V	V																		V	V																																		
K	2012	Tahoe	Body	Park Assist Module	V	V																			V																																		
K	2012	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																		
K	2012	Tahoe	Body	Passenger Presence System	V	V																			V																																		
K	2012	Tahoe	Body	Radio	V	V																		V	V																																		
K	2012	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																		
K	2012	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2012	Tahoe	Body	Right Side Object Detection Module	V	V																			V																																		
K	2012	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2012	Tahoe	Body	Theft Deterrent Module	V	V																			V																																		
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																		
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																		
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																		
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																				
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																				
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																						
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module	V	V																																																				
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Body Control Module	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Driver Door Switch	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Heated Seat Module	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2012	Tahoe Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Lift Gate Module	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Navigation Radio	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Park Assist Module	V	V																			V																																		
K	2012	Tahoe Hybrid	Body	Passenger Door Switch	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Passenger Presence System	V	V																			V																																		
K	2012	Tahoe Hybrid	Body	Radio	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module	V	V																			V																																		
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module	V	V																			V																																		
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																		
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module	V	V																			V																																		
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																						
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V													
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																						
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																		
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																		
K	2013	Avalanche	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
K	2013	Avalanche	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
K	2013	Avalanche	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2013	Avalanche	Body	Assist Step Controller	V	V																		V	V																																		
K	2013	Avalanche	Body	Body Control Module	V	V																		V	V																																		
K	2013	Avalanche	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2013	Avalanche	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2013	Avalanche	Body	Driver Door Switch	V	V																		V	V																																		
K	2013	Avalanche	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2013	Avalanche	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2013	Avalanche	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2013	Avalanche	Body	Memory Seat Module	V	V																		V	V																																		
K	2013	Avalanche	Body	Navigation Radio	V	V																		V	V																																		
K	2013	Avalanche	Body	Park Assist Module	V	V																			V																																		
K	2013	Avalanche	Body	Passenger Door Switch	V	V																		V	V																																		
K	2013	Avalanche	Body	Passenger Presence System	V	V																			V																																		
K	2013	Avalanche	Body	Radio	V	V																		V	V																																		
K	2013	Avalanche	Body	Rear Heated Seat Module	V	V																			V																																		
K	2013	Avalanche	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2013	Avalanche	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2013	Avalanche	Body	Theft Deterrent Module	V	V																			V																																		
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																						
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																	
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																	
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																						
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																	
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																	
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																	
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																	
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																	
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES	V	V																		V	V																																	
K	2013	Cheyenne	Chassis	Electronic Suspension Control	V	V																		V	V																																	
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																	
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																	
K	2013	Cheyenne	Body	Amplifier (Bose)	V	V																		V	V																																	
K	2013	Cheyenne	Body	Body Control Module	V	V																		V	V																																	
K	2013	Cheyenne	Body	Body Control Module (aux.)	V	V																		V	V																																	
K	2013	Cheyenne	Body	Digital Radio Receiver	V	V																		V	V																																	
K	2013	Cheyenne	Body	Driver Door Switch	V	V																		V	V																																	
K	2013	Cheyenne	Body	Instrument Panel Cluster	V	V																		V	V																																	
K	2013	Cheyenne	Body	Park Assist Module	V	V																			V																																	
K	2013	Cheyenne	Body	Passenger Door Switch	V	V																		V	V																																	
K	2013	Cheyenne	Body	Passenger Presence System	V	V																			V																																	
K	2013	Cheyenne	Body	Rear Heated Seat Module	V	V																			V																																	
K	2013	Cheyenne	Body	Rear HVAC/RSA	V	V																		V	V																																	
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint	V	V																			V																																	
K	2013	Cheyenne	Body	Theft Deterrent Module	V	V																			V																																	
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																						
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																	
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed	V	V																		V	V																																	
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed	V	V																		V	V																																	
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																			V													
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																						
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																	
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																	
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																	
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																	
K	2013	Suburban	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																	
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																	
K	2013	Suburban	Chassis	Electronic Suspension Control	V	V																		V	V																																	
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																	
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																	
K	2013	Suburban	Body	Amplifier (Bose)	V	V																		V	V																																	
K	2013	Suburban	Body	Assist Step Controller	V	V																		V	V																																	
K	2013	Suburban	Body	Body Control Module	V	V																		V	V																																	
K	2013	Suburban	Body	Body Control Module (aux.)	V	V																		V	V																																	
K	2013	Suburban	Body	Digital Radio Receiver	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2013	Suburban	Body	Driver Door Switch	V	V																		V	V																																				
K	2013	Suburban	Body	HVAC Control Module Auto	V	V																		V	V																																				
K	2013	Suburban	Body	HVAC Control Module Manual	V	V																		V	V																																				
K	2013	Suburban	Body	Instrument Panel Cluster	V	V																		V	V																																				
K	2013	Suburban	Body	Left Side Object Detection Module	V	V																		V	V																																				
K	2013	Suburban	Body	Lift Gate Module	V	V																		V	V																																				
K	2013	Suburban	Body	Memory Seat Module	V	V																		V	V																																				
K	2013	Suburban	Body	Navigation Radio	V	V																		V	V																																				
K	2013	Suburban	Body	Park Assist Module	V	V																			V																																				
K	2013	Suburban	Body	Passenger Door Switch	V	V																		V	V																																				
K	2013	Suburban	Body	Passenger Presence System	V	V																			V																																				
K	2013	Suburban	Body	Radio	V	V																		V	V																																				
K	2013	Suburban	Body	Rear Heated Seat Module	V	V																			V																																				
K	2013	Suburban	Body	Rear HVAC/RSA	V	V																		V	V																																				
K	2013	Suburban	Body	Right Side Object Detection Module	V	V																			V																																				
K	2013	Suburban	Body	Supplemental Inflatable Restraint	V	V																			V																																				
K	2013	Suburban	Body	Theft Deterrent Module	V	V																			V																																				
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V	V	V						V			V	V	V	V		V	V		V	V						V														V															
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V						V														V															
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																				
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V															
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																				
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																									
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module	V	V																		V	V																																				
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V															
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																				
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																								
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																				
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V															
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																				
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																				
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic	V	V			V				V		V	V	V	V	V		V	V		V	V						V														V															
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V															
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																								
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																				
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V			V				V		V	V	V	V	V		V	V		V	V						V														V															
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module	V																				V																																				
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																								
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module	V	V																		V	V																																				
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V															
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																				
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																								
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																				
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V								V						V			V	V																																				
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module		V													V					V	V																																				
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module	V	V																		V	V																																				
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module	V	V																		V										V	V	V																								
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module	V	V																		V	V																																				
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES	V	V																		V	V																																			
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																			
K	2013	Silverado	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																			
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control	V	V																		V	V																																			
K	2013	Silverado	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2013	Silverado	Body	Body Control Module	V	V																		V	V																																			
K	2013	Silverado	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2013	Silverado	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2013	Silverado	Body	Driver Door Switch	V	V																		V	V																																			
K	2013	Silverado	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2013	Silverado	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2013	Silverado	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2013	Silverado	Body	Memory Seat Module	V	V																		V	V																																			
K	2013	Silverado	Body	Navigation Radio	V	V																		V	V																																			
K	2013	Silverado	Body	Park Assist Module	V	V																			V																																			
K	2013	Silverado	Body	Passenger Door Switch	V	V																		V	V																																			
K	2013	Silverado	Body	Passenger Presence System	V	V																			V																																			
K	2013	Silverado	Body	Radio	V	V																		V	V																																			
K	2013	Silverado	Body	Rear Heated Seat Module	V	V																			V																																			
K	2013	Silverado	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2013	Silverado	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2013	Silverado	Body	Theft Deterrent Module	V	V																			V																																			
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V															
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																					
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																					
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																			
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module	V	V																																																					
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
K	2013	Silverado Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	Body Control Module	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	Heated Seat Module	V	V																			V																																			
K	2013	Silverado Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	Navigation Radio	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	Park Assist Module	V	V																			V																																			
K	2013	Silverado Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	Passenger Presence System	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2013	Silverado Hybrid	Body	Radio	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2013	Silverado Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V																				V															
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																			
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																			
K	2013	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2013	Tahoe	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2013	Tahoe	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2013	Tahoe	Body	Assist Step Controller	V	V																		V	V																																			
K	2013	Tahoe	Body	Body Control Module	V	V																		V	V																																			
K	2013	Tahoe	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2013	Tahoe	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2013	Tahoe	Body	Driver Door Switch	V	V																		V	V																																			
K	2013	Tahoe	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2013	Tahoe	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2013	Tahoe	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2013	Tahoe	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2013	Tahoe	Body	Lift Gate Module	V	V																		V	V																																			
K	2013	Tahoe	Body	Memory Seat Module	V	V																		V	V																																			
K	2013	Tahoe	Body	Navigation Radio	V	V																		V	V																																			
K	2013	Tahoe	Body	Park Assist Module	V	V																			V																																			
K	2013	Tahoe	Body	Passenger Door Switch	V	V																		V	V																																			
K	2013	Tahoe	Body	Passenger Presence System	V	V																			V																																			
K	2013	Tahoe	Body	Radio	V	V																		V	V																																			
K	2013	Tahoe	Body	Rear Heated Seat Module	V	V																			V																																			
K	2013	Tahoe	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2013	Tahoe	Body	Right Side Object Detection Module	V	V																			V																																			
K	2013	Tahoe	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2013	Tahoe	Body	Theft Deterrent Module	V	V																			V																																			
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V															
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1		V																																																					
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2		V																																																				
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module	V	V																																																					
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Body Control Module	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Heated Seat Module		V																			V																																			
K	2013	Tahoe Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Lift Gate Module	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Navigation Radio	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Park Assist Module		V																			V																																			
K	2013	Tahoe Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Passenger Presence System		V																			V																																			
K	2013	Tahoe Hybrid	Body	Radio	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module		V																			V																																			
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module		V																			V																																			
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint		V																			V																																			
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V				V	V	V	V	V													V														
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V				V	V	V	V	V													V														
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V									V	V	V	V										V													
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V														
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V										V													
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V													V														
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V										V													
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V														
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V									V	V	V	V										V													
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																			
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																			
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																			
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
K	2014	Cheyenne	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V								
K	2014	Cheyenne	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V				
K	2014	Cheyenne	Chassis	Power Steering Control Module	V	V																		V	V																																			
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
K	2014	Cheyenne	Body	Body Control Module	V	V																		V	V																																			
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
K	2014	Cheyenne	Body	Passenger Presence Module	V	V																			V																																			
K	2014	Cheyenne	Body	Instrument Cluster	V	V																		V	V																																			
K	2014	Cheyenne	Body	Radio Control	V																				V																																			
K	2014	Cheyenne	Body	HVAC Control	V																			V	V																																			
K	2014	Cheyenne	Body	Radio	V	V																		V	V																																			
K	2014	Cheyenne	Body	Amplifier	V	V																			V																																			
K	2014	Cheyenne	Body	Media Disc Player	V	V																		V	V																																			
K	2014	Cheyenne	Body	Human Machine Interface Control Module	V	V																		V	V																					V														
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2014	Cheyenne	Body	HVAC Control Module	V	V																		V	V																																			
K	2014	Cheyenne	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
K	2014	Cheyenne	Body	Parking Assist Control Module	V																			V	V																																			
K	2014	Cheyenne	Body	Frontview Camera Module	V	V																		V	V																																			
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V			V	V	V	V	V													V														
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V			V	V	V	V	V													V														
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V			V	V	V	V	V													V														
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V			V	V	V	V	V													V														
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module	V	V																		V	V									V	V	V	V		V																			
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																		
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																		
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																		
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
K	2014	Silverado	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
K	2014	Silverado	Chassis	Parking Brake Control Module	V	V																			V																				V								V	V	V	V		
K	2014	Silverado	Chassis	Power Steering Control Module	V	V																		V	V																																		
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
K	2014	Silverado	Body	Body Control Module	V	V																		V	V																																		
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
K	2014	Silverado	Body	Passenger Presence Module	V	V																			V																																		
K	2014	Silverado	Body	Instrument Cluster	V	V																		V	V																																		
K	2014	Silverado	Body	Radio Control	V																				V																																		
K	2014	Silverado	Body	HVAC Control	V																			V	V																																		
K	2014	Silverado	Body	Radio	V	V																		V	V																																		
K	2014	Silverado	Body	Amplifier	V	V																			V																																		
K	2014	Silverado	Body	Media Disc Player	V	V																		V	V																																		
K	2014	Silverado	Body	Human Machine Interface Control Module	V	V																		V	V																					V													
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																		
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																		
K	2014	Silverado	Body	Parking Assist Control Module	V																			V	V																																		
K	2014	Silverado	Body	Frontview Camera Module	V	V																		V	V																																		
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module	V	V																		V	V									V	V	V	V									V													
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V			V	V	V	V	V													V														
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V			V	V	V	V	V													V														
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module	V	V																		V																																		
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module	V																			V	V						V		V																									
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module		V								V					V					V	V																																		
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module	V	V																		V	V									V	V	V	V		V																			
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																		
K	2014	Silverado HD	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
K	2014	Silverado HD	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V						V
K	2014	Silverado HD	Chassis	Trailer Brake Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2014	Silverado HD	Chassis	Suspension Control Module	V	V																		V	V																																				
K	2014	Silverado HD	Body	Body Control Module	V	V																		V	V																																				
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																				
K	2014	Silverado HD	Body	Passenger Presence Module	V	V																			V																																				
K	2014	Silverado HD	Body	Instrument Cluster	V	V																		V	V																																				
K	2014	Silverado HD	Body	Chime Alarm Control Module	V																			V	V																																				
K	2014	Silverado HD	Body	Base Radio	V	V																		V	V																																				
K	2014	Silverado HD	Body	Navigation Radio	V	V																		V	V																																				
K	2014	Silverado HD	Body	Uplevel Radio	V	V																		V	V																																				
K	2014	Silverado HD	Body	Amplifier	V	V																			V																																				
K	2014	Silverado HD	Body	Rear Audio Control Module	V	V																			V																																				
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module	V	V																		V	V																																				
K	2014	Silverado HD	Body	Personal Audio Link Control Module	V																				V																																				
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																				
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																				
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																				
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																				
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)	V	V																		V	V																																				
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																				
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module	V	V																		V	V																							V												
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																				
K	2014	Silverado HD	Body	Seat Memory Control Module	V	V																		V	V																																				
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
K	2014	Silverado HD	Body	Parking Assist Control Module	V	V																		V	V																																				
K	2014	Silverado HD	Body	Theft Deterrent Module	V	V																			V																																				
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module	V																			V	V	V			V	V	V	V	V													V															
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module	V	V																		V	V										V	V	V	V										V													
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module	V																			V	V	V			V	V	V	V	V													V															
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module	V	V																		V	V										V	V	V	V										V													
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V																													
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control	V	V									V									V	V							V																													
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																				
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																				
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																				
K	2014	Suburban	Chassis	Electronic Brake Control Module	V	V																		V	V													V											V	V	V	V	V	V						V
K	2014	Suburban	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V			
K	2014	Suburban	Chassis	Suspension Control Module	V	V																		V	V																																				
K	2014	Suburban	Body	Body Control Module	V	V																		V	V																																				
K	2014	Suburban	Body	Auxiliary Body Control Module	V	V																		V	V																																				
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																				
K	2014	Suburban	Body	Passenger Presence Module	V	V																			V																																				
K	2014	Suburban	Body	Instrument Cluster	V	V																		V	V																																				
K	2014	Suburban	Body	Base Radio	V	V																		V	V																																				
K	2014	Suburban	Body	Navigation Radio	V	V																		V	V																																				
K	2014	Suburban	Body	Uplevel Radio	V	V																		V	V																																				
K	2014	Suburban	Body	Amplifier	V	V																			V																																				
K	2014	Suburban	Body	Rear Audio Control Module	V	V																			V																																				
K	2014	Suburban	Body	Digital Radio Receiver Control Module	V	V																		V	V																																				
K	2014	Suburban	Body	Personal Audio Link Control Module	V																				V																																				
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																				
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)	V	V																		V	V																																			
K	2014	Suburban	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V													
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																			
K	2014	Suburban	Body	Liftgate Control Module	V	V																			V																						V													
K	2014	Suburban	Body	Seat Memory Control Module	V	V																		V	V																																			
K	2014	Suburban	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
K	2014	Suburban	Body	Assist Step Control Module	V	V																		V	V																																			
K	2014	Suburban	Body	Right Side Object Detection Control Module	V	V																		V	V																																			
K	2014	Suburban	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
K	2014	Suburban	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
K	2014	Suburban	Body	Parking Assist Control Module	V	V																		V	V																																			
K	2014	Suburban	Body	Theft Deterrent Module	V	V																			V																																			
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module	V																			V	V	V			V	V	V	V	V													V														
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module	V	V																		V	V									V	V	V	V									V														
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V																												
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control	V	V									V									V	V							V																												
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
K	2014	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V					V
K	2014	Tahoe	Chassis	Parking Brake Control Module	V	V																			V																					V						V	V	V	V		
K	2014	Tahoe	Chassis	Suspension Control Module	V	V																		V	V																																			
K	2014	Tahoe	Body	Body Control Module	V	V																		V	V																																			
K	2014	Tahoe	Body	Auxiliary Body Control Module	V	V																		V	V																																			
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
K	2014	Tahoe	Body	Passenger Presence Module	V	V																			V																																			
K	2014	Tahoe	Body	Instrument Cluster	V	V																		V	V																																			
K	2014	Tahoe	Body	Base Radio	V	V																		V	V																																			
K	2014	Tahoe	Body	Navigation Radio	V	V																		V	V																																			
K	2014	Tahoe	Body	Uplevel Radio	V	V																		V	V																																			
K	2014	Tahoe	Body	Amplifier	V	V																			V																																			
K	2014	Tahoe	Body	Rear Audio Control Module	V	V																			V																																			
K	2014	Tahoe	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
K	2014	Tahoe	Body	Personal Audio Link Control Module	V																				V																																			
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)	V	V																		V	V																																			
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V													
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																			
K	2014	Tahoe	Body	Liftgate Control Module	V	V																			V																						V													
K	2014	Tahoe	Body	Seat Memory Control Module	V	V																		V	V																																			
K	2014	Tahoe	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
K	2014	Tahoe	Body	Assist Step Control Module	V	V																		V	V																																			
K	2014	Tahoe	Body	Right Side Object Detection Control Module	V	V																		V	V																																			
K	2014	Tahoe	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
K	2014	Tahoe	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
K	2014	Tahoe	Body	Parking Assist Control Module	V	V																		V	V																																			
K	2014	Tahoe	Body	Theft Deterrent Module	V	V																			V																																			
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V				V	V	V	V	V													V														
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V				V	V	V	V	V													V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module	V	V																		V																																		
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																		
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																		
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																		
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																		
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)	V	V																		V	V																																		
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
K	2015	Cheyenne	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V							
K	2015	Cheyenne	Chassis	Power Steering Control Module	V	V																		V	V																																		
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
K	2015	Cheyenne	Chassis	Suspension Control Module	V	V																		V	V																																		
K	2015	Cheyenne	Body	Body Control Module	V	V																		V	V																																		
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
K	2015	Cheyenne	Body	Passenger Presence Module	V	V																			V																																		
K	2015	Cheyenne	Body	Instrument Cluster	V	V																		V	V																																		
K	2015	Cheyenne	Body	Radio Controls	V																				V																																		
K	2015	Cheyenne	Body	HVAC Controls	V																			V	V																																		
K	2015	Cheyenne	Body	Radio	V	V																		V	V																																		
K	2015	Cheyenne	Body	Amplifier	V	V																			V																																		
K	2015	Cheyenne	Body	Media Disc Player	V	V																		V	V																																		
K	2015	Cheyenne	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
K	2015	Cheyenne	Body	HVAC Control Module	V	V																		V	V																																		
K	2015	Cheyenne	Body	Parking Assist Control Module	V																			V	V																																		
K	2015	Cheyenne	Body	Frontview Camera Module	V	V																		V	V																																		
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module	V	V																		V																																		
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V														
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																			
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module	V																			V	V						V		V																										
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module		V								V					V					V	V																																		
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)	V	V																		V	V									V	V	V	V		V																			
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)	V	V																		V	V									V	V	V	V		V																			
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																			
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																		
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																		
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																		
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)	V	V																		V	V																																		
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
K	2015	Silverado	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
K	2015	Silverado	Chassis	Power Steering Control Module	V	V																		V	V																																		
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
K	2015	Silverado	Chassis	Suspension Control Module	V	V																		V	V																																		
K	2015	Silverado	Body	Body Control Module	V	V																		V	V																																		
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
K	2015	Silverado	Body	Passenger Presence Module	V	V																			V																																		
K	2015	Silverado	Body	Instrument Cluster	V	V																		V	V																																		
K	2015	Silverado	Body	Radio Controls	V																				V																																		
K	2015	Silverado	Body	HVAC Controls	V																			V	V																																		
K	2015	Silverado	Body	Radio	V	V																		V	V																																		
K	2015	Silverado	Body	Amplifier	V	V																			V																																		
K	2015	Silverado	Body	Media Disc Player	V	V																		V	V																																		
K	2015	Silverado	Body	Human Machine Interface Control Module	V	V																		V	V																																		
K	2015	Silverado	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																		
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																		
K	2015	Silverado	Body	Parking Assist Control Module	V																			V	V																																		
K	2015	Silverado	Body	Frontview Camera Module	V	V																		V	V																																		
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V			V	V	V	V	V													V													
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V			V	V	V	V	V													V													
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																		
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																		
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control	V	V																		V	V																																		
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																		
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
K	2015	Suburban	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
K	2015	Suburban	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		
K	2015	Suburban	Chassis	Power Steering Control Module	V	V																		V	V																																		
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
K	2015	Suburban	Chassis	Suspension Control Module	V	V																		V	V																																		
K	2015	Suburban	Body	Body Control Module	V	V																		V	V																																		
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
K	2015	Suburban	Body	Passenger Presence Module	V	V																			V																																		
K	2015	Suburban	Body	Instrument Cluster	V	V																		V	V																																		
K	2015	Suburban	Body	Radio Controls	V																				V																																		
K	2015	Suburban	Body	HVAC Controls	V																			V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2015	Suburban	Body	Radio	V	V																		V	V																																			
K	2015	Suburban	Body	Amplifier	V	V																			V																																		
K	2015	Suburban	Body	Media Disc Player	V	V																		V	V																																		
K	2015	Suburban	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																		
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
K	2015	Suburban	Body	HVAC Control Module	V	V																		V	V																																		
K	2015	Suburban	Body	Liftgate Control Module	V	V																			V																							V											
K	2015	Suburban	Body	Keyless Entry Control Module	V	V																		V	V																																		
K	2015	Suburban	Body	Assist Step Control Module	V	V																		V	V																																		
K	2015	Suburban	Body	Left Side Object Detection Control Module	V																			V	V																																		
K	2015	Suburban	Body	Parking Assist Control Module	V																			V	V																																		
K	2015	Suburban	Body	Frontview Camera Module	V	V																			V																																		
K	2015	Suburban	Body	Steering Column Lock Control Module	V	V																			V																																		
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V													
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V													
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																		
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																		
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control	V	V																		V	V																																		
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																		
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1		V																			V																																		
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2		V																			V																																		
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																		
K	2015	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
K	2015	Tahoe	Chassis	Parking Brake Control Module	V	V																			V																							V						V	V	V	V		
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		
K	2015	Tahoe	Chassis	Power Steering Control Module	V	V																		V	V																																		
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
K	2015	Tahoe	Chassis	Suspension Control Module	V	V																		V	V																																		
K	2015	Tahoe	Body	Body Control Module	V	V																		V	V																																		
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
K	2015	Tahoe	Body	Passenger Presence Module	V	V																			V																																		
K	2015	Tahoe	Body	Instrument Cluster	V	V																		V	V																																		
K	2015	Tahoe	Body	Radio Controls	V																				V																																		
K	2015	Tahoe	Body	HVAC Controls	V																			V	V																																		
K	2015	Tahoe	Body	Radio	V	V																		V	V																																		
K	2015	Tahoe	Body	Amplifier	V	V																			V																																		
K	2015	Tahoe	Body	Media Disc Player	V	V																		V	V																																		
K	2015	Tahoe	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																		
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
K	2015	Tahoe	Body	HVAC Control Module	V	V																		V	V																																		
K	2015	Tahoe	Body	Liftgate Control Module	V	V																			V																							V											
K	2015	Tahoe	Body	Keyless Entry Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2015	Tahoe	Body	Assist Step Control Module	V	V																		V	V																																			
K	2015	Tahoe	Body	Left Side Object Detection Control Module	V																			V	V																																			
K	2015	Tahoe	Body	Parking Assist Control Module	V																			V	V																																			
K	2015	Tahoe	Body	Frontview Camera Module	V	V																		V	V																																			
K	2015	Tahoe	Body	Steering Column Lock Control Module	V	V																			V																																			
K	2015	Tahoe	Body	Battery Energy Control Module		V																			V																																			
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V														
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V										V													
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V														
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V									V	V	V	V		V																				
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module	V	V																		V																																			
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																			
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)	V	V																		V	V																																			
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
K	2016	Cheyenne	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V							
K	2016	Cheyenne	Chassis	Power Steering Control Module	V	V																		V	V																																			
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
K	2016	Cheyenne	Chassis	Suspension Control Module	V	V																		V	V																																			
K	2016	Cheyenne	Body	Body Control Module	V	V																		V	V																																			
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
K	2016	Cheyenne	Body	Passenger Presence Module	V	V																			V																																			
K	2016	Cheyenne	Body	Instrument Cluster	V	V																		V	V																																			
K	2016	Cheyenne	Body	Radio Controls	V																				V																																			
K	2016	Cheyenne	Body	HVAC Controls	V																			V	V																																			
K	2016	Cheyenne	Body	Radio	V	V																		V	V																																			
K	2016	Cheyenne	Body	Amplifier	V	V																			V																																			
K	2016	Cheyenne	Body	Media Disc Player	V	V																		V	V																																			
K	2016	Cheyenne	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
K	2016	Cheyenne	Body	HVAC Control Module	V	V																		V	V																																			
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module	V	V																		V	V																																			
K	2016	Cheyenne	Body	Parking Assist Control Module	V																			V	V																																			
K	2016	Cheyenne	Body	Frontview Camera Module	V	V																		V	V																																			
K	2016	Cheyenne	Body	Frontview Camera Module	V	V																		V	V																																			
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V									V	V	V	V										V													
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V										V													
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																			
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module	V	V																		V	V									V	V	V	V		V																			
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module	V	V	V	V																V	V																																		
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2	V	V																		V	V																																		
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V										V													
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module	V	V																		V																																			
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V										V													
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V														
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																				
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module	V																			V	V					V		V																												
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module		V								V					V					V	V																																			
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module	V	V																		V	V									V	V	V	V		V																				
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																		
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																		
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)	V	V																		V	V																																		
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
K	2016	Silverado	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
K	2016	Silverado	Chassis	Power Steering Control Module	V	V																			V																																		
K	2016	Silverado	Chassis	Power Steering Control Module	V	V																		V	V																																		
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
K	2016	Silverado	Chassis	Suspension Control Module	V	V																		V	V																																		
K	2016	Silverado	Body	Body Control Module	V	V																		V	V																																		
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
K	2016	Silverado	Body	Passenger Presence Module	V	V																			V																																		
K	2016	Silverado	Body	Instrument Cluster	V	V																		V	V																																		
K	2016	Silverado	Body	Radio Controls	V																				V																																		
K	2016	Silverado	Body	HVAC Controls	V																			V	V																																		
K	2016	Silverado	Body	Radio (IO3)	V	V																		V	V																																		
K	2016	Silverado	Body	Radio (IOB)	V	V																		V	V																																		
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)	V	V																		V	V																																		
K	2016	Silverado	Body	Amplifier	V	V																			V																																		
K	2016	Silverado	Body	Media Disc Player	V	V																		V	V																																		
K	2016	Silverado	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																		
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																		
K	2016	Silverado	Body	Seat Memory Control Module - Driver	V																																																					
K	2016	Silverado	Body	Assist Step Object Detection Control Module	V	V																		V	V																																		
K	2016	Silverado	Body	Parking Assist Control Module	V																			V	V																																		
K	2016	Silverado	Body	Frontview Camera Module	V	V																		V	V																																		
K	2016	Silverado	Body	Frontview Camera Module	V	V																		V	V																																		
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V												V														
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
K	2016	Suburban	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
K	2016	Suburban	Chassis	Parking Brake Control Module	V	V																			V																						V						V	V	V	V		
K	2016	Suburban	Chassis	Power Steering Control Module	V	V																		V	V																																		
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
K	2016	Suburban	Chassis	Suspension Control Module	V	V																		V	V																																		
K	2016	Suburban	Body	Body Control Module	V	V																		V	V																																		
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2016	Suburban	Body	Passenger Presence Module	V	V																			V																																			
K	2016	Suburban	Body	Instrument Cluster	V	V																		V	V																																			
K	2016	Suburban	Body	Radio Controls	V																				V																																			
K	2016	Suburban	Body	HVAC Controls	V																			V	V																																			
K	2016	Suburban	Body	Radio	V	V																		V	V																																			
K	2016	Suburban	Body	Amplifier	V	V																			V																																			
K	2016	Suburban	Body	Media Disc Player	V	V																		V	V																																			
K	2016	Suburban	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
K	2016	Suburban	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
K	2016	Suburban	Body	HVAC Control Module	V	V																		V	V																																			
K	2016	Suburban	Body	Liftgate Control Module	V	V																		V	V																							V											
K	2016	Suburban	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
K	2016	Suburban	Body	Seat Memory Control Module - Driver	V																																																							
K	2016	Suburban	Body	Keyless Entry Control Module	V	V																		V	V																																			
K	2016	Suburban	Body	Assist Step Control Module	V	V																		V	V																																			
K	2016	Suburban	Body	Left Side Object Detection Control Module	V																			V	V																																			
K	2016	Suburban	Body	Parking Assist Control Module	V																			V	V																																			
K	2016	Suburban	Body	Frontview Camera Module	V	V																		V	V																																			
K	2016	Suburban	Body	Steering Column Lock Control Module	V	V																			V																																			
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V														
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
K	2016	Tahoe	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
K	2016	Tahoe	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
K	2016	Tahoe	Chassis	Power Steering Control Module	V	V																		V	V																																			
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
K	2016	Tahoe	Chassis	Suspension Control Module	V	V																		V	V																																			
K	2016	Tahoe	Body	Body Control Module	V	V																		V	V																																			
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
K	2016	Tahoe	Body	Passenger Presence Module	V	V																			V																																			
K	2016	Tahoe	Body	Instrument Cluster	V	V																		V	V																																			
K	2016	Tahoe	Body	Radio Controls	V																				V																																			
K	2016	Tahoe	Body	HVAC Controls	V																			V	V																																			
K	2016	Tahoe	Body	Radio	V	V																		V	V																																			
K	2016	Tahoe	Body	Amplifier	V	V																			V																																			
K	2016	Tahoe	Body	Media Disc Player	V	V																		V	V																																			
K	2016	Tahoe	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
K	2016	Tahoe	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
K	2016	Tahoe	Body	HVAC Control Module	V	V																		V	V																																			
K	2016	Tahoe	Body	Liftgate Control Module	V	V																		V	V																							V											
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
K	2016	Tahoe	Body	Seat Memory Control Module - Driver	V																																																						
K	2016	Tahoe	Body	Keyless Entry Control Module	V	V																		V	V																																			
K	2016	Tahoe	Body	Assist Step Control Module	V	V																		V	V																																			
K	2016	Tahoe	Body	Left Side Object Detection Control Module	V																			V	V																																			
K	2016	Tahoe	Body	Parking Assist Control Module	V																			V	V																																			
K	2016	Tahoe	Body	Frontview Camera Module	V	V																		V	V																																			
K	2016	Tahoe	Body	Steering Column Lock Control Module	V	V																			V																																			
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display	V	V																		V																																				
L	2004	ALL	Chassis	4WAL 3 Sensor	V	V																		V																																				
L	2004	ALL	Body	Body Control Module	V	V																		V																																				
L	2004	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
L	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display	V	V																		V																																				
L	2005	Astro	Chassis	4WAL 3 Sensor	V	V																		V																																				
L	2005	Astro	Body	Body Control Module	V	V																		V																																				
L	2005	Astro	Body	Instrument Panel Cluster	V	V																		V	V																																			
L	2005	Astro	Body	Supplemental Inflatable Restraint	V	V																																																					
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module	V	V																		V										V	V	V																							
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes	V	V																		V	V																																		
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No	V	V																		V	V																																		
L	2005	Equinox	Chassis	Electric Power Steering	V	V																																																				
L	2005	Equinox	Body	Body Control Module	V	V																		V	V																																		
L	2005	Equinox	Body	Instrument Panel Cluster																				V	V																																		
L	2005	Equinox	Body	Radio	V	V																		V																																			
L	2005	Equinox	Body	Supplemental Inflatable Restraint	V	V																																																				
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module	V	V																		V										V	V	V																							
L	2006	ALL	Chassis	Traction Control Yes	V	V																		V	V																																		
L	2006	ALL	Chassis	Traction Control No	V	V																		V	V																																		
L	2006	ALL	Chassis	Electric Power Steering	V	V																																																				
L	2006	ALL	Body	Body Control Module	V	V																		V	V																																		
L	2006	ALL	Body	Instrument Panel Cluster																				V	V																																		
L	2006	ALL	Body	Radio	V	V																		V																																			
L	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module	V	V																		V										V	V	V																							
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System	V	V																			V																																		
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control	V	V																		V	V																																		
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control	V	V																		V	V																																		
L	2007	ALL	Chassis	Power Steering Control Module	V	V																																																				
L	2007	ALL	Body	Body Control Module	V	V																		V	V																																		
L	2007	ALL	Body	Digital Radio Receiver	V	V																			V																																		
L	2007	ALL	Body	Heated Seat Module	V	V																			V																																		
L	2007	ALL	Body	HVAC Control Module	V	V																		V	V																																		
L	2007	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
L	2007	ALL	Body	Passenger Presence System	V	V																			V																																		
L	2007	ALL	Body	Radio	V	V																		V	V																																		
L	2007	ALL	Body	Rollover Sensor	V	V																			V																																		
L	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
L	2007	ALL	Body	Theft Deterrent Module	V	V																			V																																		
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module	V	V																		V										V	V																								
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V			V		V	V		V	V							V								V	V	V	V		V													
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V	V																								
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
L	2008	Captiva Sport	Body	Body Control Module	V	V																		V	V																																			
L	2008	Captiva Sport	Body	Digital Radio Receiver	V	V																			V																																			
L	2008	Captiva Sport	Body	HVAC Control Module Auto	V	V																		V	V																																			
L	2008	Captiva Sport	Body	HVAC Control Module Manual	V	V																		V	V																																			
L	2008	Captiva Sport	Body	Instrument Panel Cluster	V	V																		V	V																																			
L	2008	Captiva Sport	Body	Passenger Presence System	V	V																			V																																			
L	2008	Captiva Sport	Body	Radio	V	V																		V	V																																			
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
L	2008	Captiva Sport	Body	Rollover Sensor	V	V																			V																																			
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint	V	V																			V																																			
L	2008	Captiva Sport	Body	Theft Deterrent Module	V	V																			V																																			
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V												
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System	V	V																			V																																			
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module	V	V																		V										V	V	V																								
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V															
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System	V	V																			V																																			
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V	V																								
L	2008	Equinox	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
L	2008	Equinox	Chassis	Power Steering Control Module	V	V																																																					
L	2008	Equinox	Body	Body Control Module	V	V																		V	V																																			
L	2008	Equinox	Body	Digital Radio Receiver	V	V																			V																																			
L	2008	Equinox	Body	Heated Seat Module	V	V																			V																																			
L	2008	Equinox	Body	HVAC Control Module	V	V																		V	V																																			
L	2008	Equinox	Body	Instrument Panel Cluster	V	V																		V	V																																			
L	2008	Equinox	Body	Passenger Presence System	V	V																			V																																			
L	2008	Equinox	Body	Radio	V	V																		V	V																																			
L	2008	Equinox	Body	Rollover Sensor	V	V																			V																																			
L	2008	Equinox	Body	Supplemental Inflatable Restraint	V	V																			V																																			
L	2008	Equinox	Body	Theft Deterrent Module	V	V																			V																																			
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V												
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module	V	V																		V										V	V																								
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V												
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module	V	V																		V										V	V																								
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V			V		V	V		V	V							V								V	V	V	V		V												
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System	V	V																			V																																			
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V	V																								
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
L	2009	Captiva Sport	Chassis	Power Steering Control Module	V	V																																																					
L	2009	Captiva Sport	Body	Body Control Module	V	V																		V	V																																			
L	2009	Captiva Sport	Body	HVAC Control Module Auto	V	V																		V	V																																			
L	2009	Captiva Sport	Body	HVAC Control Module Manual	V	V																		V	V																																			
L	2009	Captiva Sport	Body	Instrument Panel Cluster	V	V																		V	V																																			
L	2009	Captiva Sport	Body	Passenger Presence System	V	V																			V																																			
L	2009	Captiva Sport	Body	Radio	V	V																		V	V																																			
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
L	2009	Captiva Sport	Body	Rollover Sensor	V	V																			V																																			
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint	V	V																			V																																			
L	2009	Captiva Sport	Body	Theft Deterrent Module	V	V																			V																																			
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System	V	V																			V																																				
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module	V	V																		V										V	V	V																								
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V								V	V	V	V																
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System	V	V																			V																																			
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V	V																								
L	2009	Equinox	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
L	2009	Equinox	Chassis	Power Steering Control Module	V	V																																																						
L	2009	Equinox	Body	Body Control Module	V	V																		V	V																																			
L	2009	Equinox	Body	Digital Radio Receiver	V	V																		V	V																																			
L	2009	Equinox	Body	Heated Seat Module	V	V																			V																																			
L	2009	Equinox	Body	HVAC Control Module	V	V																		V	V																																			
L	2009	Equinox	Body	Instrument Panel Cluster	V	V																		V	V																																			
L	2009	Equinox	Body	Passenger Presence System	V	V																			V																																			
L	2009	Equinox	Body	Radio	V	V																		V	V																																			
L	2009	Equinox	Body	Rollover Sensor	V	V																			V																																			
L	2009	Equinox	Body	Supplemental Inflatable Restraint	V	V																			V																																			
L	2009	Equinox	Body	Theft Deterrent Module	V	V																			V																																			
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module	V	V																		V	V																																			
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module	V	V																		V										V	V																									
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module	V	V																		V	V																																			
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module	V	V																		V										V	V																									
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V	V	V		V				V			V			V		V	V		V	V							V								V	V	V	V		V														
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module	V	V																		V	V																																			
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System	V	V																			V																																			
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module	V	V																		V										V	V	V																								
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
L	2010	Captiva Sport	Chassis	Power Steering Control Module	V	V																																																						
L	2010	Captiva Sport	Body	Body Control Module	V	V																		V	V																																			
L	2010	Captiva Sport	Body	HVAC Control Module	V	V																		V	V																																			
L	2010	Captiva Sport	Body	Instrument Panel Cluster	V	V																		V	V																																			
L	2010	Captiva Sport	Body	Passenger Presence System	V	V																			V																																			
L	2010	Captiva Sport	Body	Radio	V	V																		V	V																																			
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
L	2010	Captiva Sport	Body	Rollover Sensor	V	V																			V																																			
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint	V	V																			V																																			
L	2010	Captiva Sport	Body	Theft Deterrent Module	V	V																			V																																			
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																												
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V															
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
L	2010	Equinox	Powertrain	Fuel Pump Control Module	V	V																		V	V							V			V																									
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																			
L	2010	Equinox	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
L	2010	Equinox	Body	Body Control Module	V	V																		V	V																																			
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
L	2010	Equinox	Body	Passenger Presence Module	V	V																			V																																			
L	2010	Equinox	Body	Instrument Cluster	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2010	Equinox	Body	Radio	V	V																		V	V																																		
L	2010	Equinox	Body	Multimedia Player Interface Module	V	V																			V																																		
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
L	2010	Equinox	Body	Liftgate Control Module	V	V																			V																					V												
L	2010	Equinox	Body	Parking Assist Control Module	V																				V																																		
L	2010	Equinox	Body	Frontview Camera Module	V	V																		V	V																																		
L	2010	Equinox	Body	Vehicle Direction Camera Control Module	V	V																		V	V																																		
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																												
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V														V													
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission	V																			V	V			V			V																												
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission	V																			V	V			V			V														V													
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V													
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module	V	V																		V	V							V		V																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V													
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V									V	V	V	V		V												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V									V	V	V	V	V	V												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module	V	V																		V	V							V		V																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																		
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																	
L	2011	Captiva	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					V
L	2011	Captiva	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
L	2011	Captiva	Body	Body Control Module	V	V																		V	V																																		
L	2011	Captiva	Body	Auxiliary Body Control Module	V	V																		V	V																																		
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
L	2011	Captiva	Body	Instrument Cluster	V	V																		V	V																																		
L	2011	Captiva	Body	Headlamp Control Module	V	V																		V	V																																		
L	2011	Captiva	Body	HVAC Control Module	V																			V	V																																		
L	2011	Captiva	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
L	2011	Captiva	Body	Parking Assist Control Module	V	V																		V	V																																		
L	2011	Captiva	Body	Theft Deterrent Module	V	V																			V																																		
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V				V													
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module	V	V																		V	V																																		
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System	V	V																			V																																		
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module	V	V																		V											V	V	V																						
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V													
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module	V	V																		V	V																																		
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System	V	V																			V																																		
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module	V	V																		V											V	V	V																						
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V													
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module	V	V																		V	V																																		
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System	V	V																			V																																		
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module	V	V																		V											V	V	V																						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
L	2011	Captiva Sport	Chassis	Parking Brake Control Module		V																		V	V																																			
L	2011	Captiva Sport	Body	Body Control Module	V	V																		V	V																																			
L	2011	Captiva Sport	Body	Digital Radio Receiver	V	V																		V	V																																			
L	2011	Captiva Sport	Body	HVAC Control Module	V	V																		V	V																																			
L	2011	Captiva Sport	Body	Instrument Panel Cluster	V	V																		V	V																																			
L	2011	Captiva Sport	Body	Passenger Presence System	V	V																			V																																			
L	2011	Captiva Sport	Body	Radio	V	V																		V	V																																			
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
L	2011	Captiva Sport	Body	Rollover Sensor	V	V																			V																																			
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint	V	V																			V																																			
L	2011	Captiva Sport	Body	Theft Deterrent Module	V	V																			V																																			
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																												
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V														
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V									V													
L	2011	Equinox	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																										
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																			
L	2011	Equinox	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
L	2011	Equinox	Body	Body Control Module	V	V																		V	V																																			
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
L	2011	Equinox	Body	Passenger Presence Module	V	V																			V																																			
L	2011	Equinox	Body	Instrument Cluster	V	V																		V	V																																			
L	2011	Equinox	Body	Radio	V	V																		V	V																																			
L	2011	Equinox	Body	Multimedia Player Interface Module	V	V																			V																																			
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
L	2011	Equinox	Body	Liftgate Control Module	V	V																			V																							V											
L	2011	Equinox	Body	Parking Assist Control Module	V																				V																																			
L	2011	Equinox	Body	Frontview Camera Module	V	V																		V	V																																			
L	2011	Equinox	Body	Vehicle Direction Camera Control Module	V	V																		V	V																																			
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																													
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V														V														
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission	V																			V	V			V			V																													
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission	V																			V	V			V			V														V														
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																												
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V																
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module	V	V																		V	V							V		V																										
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																												
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V																
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module	V	V																		V	V							V		V																										
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V								V	V	V	V		V															
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V								V	V	V	V	V	V															

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V									V	V	V	V		V													
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V									V	V	V	V	V	V													
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module	V	V																		V	V							V		V																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																	
L	2012	Captiva	Chassis	Electronic Brake Control Module	V	V																		V	V																											V					V
L	2012	Captiva	Chassis	Parking Brake Control Module	V	V																			V																					V						V	V	V	V		
L	2012	Captiva	Body	Body Control Module	V	V																		V	V																																	
L	2012	Captiva	Body	Auxiliary Body Control Module	V	V																		V	V																																	
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
L	2012	Captiva	Body	Instrument Cluster	V	V																		V	V																																	
L	2012	Captiva	Body	Headlamp Control Module	V	V																		V	V																																	
L	2012	Captiva	Body	HVAC Control Module	V																			V	V																																	
L	2012	Captiva	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
L	2012	Captiva	Body	Parking Assist Control Module	V	V																		V	V																																	
L	2012	Captiva	Body	Theft Deterrent Module	V	V																			V																																	
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V				V													
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module	V	V																		V	V																																	
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System	V	V																			V																																	
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module	V	V																		V											V	V	V																					
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V													
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module	V	V																		V	V																																	
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System	V	V																			V																																	
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module	V	V																		V											V	V	V																					
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module	V	V																		V	V																																	
L	2012	Captiva Sport	Chassis	Parking Brake Control Module		V																		V	V																																	
L	2012	Captiva Sport	Body	Body Control Module	V	V																		V	V																																	
L	2012	Captiva Sport	Body	Digital Radio Receiver	V	V																		V	V																																	
L	2012	Captiva Sport	Body	HVAC Control Module	V	V																		V	V																																	
L	2012	Captiva Sport	Body	Instrument Panel Cluster	V	V																		V	V																																	
L	2012	Captiva Sport	Body	Passenger Presence System	V	V																			V																																	
L	2012	Captiva Sport	Body	Radio	V	V																		V	V																																	
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
L	2012	Captiva Sport	Body	Rollover Sensor	V	V																			V																																	
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint	V	V																			V																																	
L	2012	Captiva Sport	Body	Theft Deterrent Module	V	V																			V																																	
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																									
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V				V	V	V	V	V	V							V	V	V	V	V	V													
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V										V	V	V	V								V													
L	2012	Equinox	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																									
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																	
L	2012	Equinox	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V						V
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
L	2012	Equinox	Body	Body Control Module	V	V																		V	V																																	
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
L	2012	Equinox	Body	Passenger Presence Module	V	V																			V																																	
L	2012	Equinox	Body	Instrument Cluster	V	V																		V	V																																	
L	2012	Equinox	Body	Radio	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2012	Equinox	Body	Multimedia Player Interface Module	V	V																			V																																			
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
L	2012	Equinox	Body	Liftgate Control Module	V	V																			V																					V													
L	2012	Equinox	Body	Parking Assist Control Module	V																			V	V																																		
L	2012	Equinox	Body	Frontview Camera Module	V	V																		V	V																																		
L	2012	Equinox	Body	Vehicle Direction Camera Control Module	V	V																		V	V																																		
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																												
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V														V													
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission	V																			V	V			V			V																												
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission	V																			V	V			V			V														V													
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V																											
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V														V													
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V																											
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V														V													
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module	V	V																		V	V						V		V																									
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V													
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V								V	V	V	V	V	V													
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
L	2013	Captiva	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					V
L	2013	Captiva	Chassis	Parking Brake Control Module	V	V																			V																				V								V	V	V	V		
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto	V	V																		V	V																																		
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual	V	V																		V	V																																		
L	2013	Captiva	Body	Auxiliary Body Control Module	V	V																		V	V																																		
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
L	2013	Captiva	Body	Instrument Cluster	V	V																		V	V																																		
L	2013	Captiva	Body	Headlamp Control Module	V	V																		V	V																																		
L	2013	Captiva	Body	HVAC Control Module	V																			V	V																																		
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)	V	V																		V	V																																		
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)	V	V																		V	V																																		
L	2013	Captiva	Body	Theft Deterrent Module	V	V																			V																																		
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V				V													
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System	V	V																			V																																		
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module	V	V																		V										V	V	V																						
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V													
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System	V	V																			V																																		
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module	V	V																		V										V	V	V																						
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
L	2013	Captiva Sport	Chassis	Parking Brake Control Module		V																		V	V																																		
L	2013	Captiva Sport	Body	Body Control Module	V	V																		V	V																																		
L	2013	Captiva Sport	Body	Digital Radio Receiver	V	V																		V	V																																		
L	2013	Captiva Sport	Body	Heated Seat Module	V	V																			V																																		
L	2013	Captiva Sport	Body	HVAC Control Module	V	V																		V	V																																		
L	2013	Captiva Sport	Body	Instrument Panel Cluster	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2013	Captiva Sport	Body	Park Assist Module	V	V																			V																																			
L	2013	Captiva Sport	Body	Passenger Presence System	V	V																			V																																			
L	2013	Captiva Sport	Body	Radio	V	V																		V	V																																			
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint	V	V																			V																																			
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.	V	V																			V																																			
L	2013	Captiva Sport	Body	Theft Deterrent Module	V	V																			V																																			
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V																										
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V													
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V												
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																			
L	2013	Equinox	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
L	2013	Equinox	Chassis	Power Steering Control Module	V	V																			V																																			
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																			
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																			
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
L	2013	Equinox	Body	Passenger Presence Module	V	V																			V																																			
L	2013	Equinox	Body	Instrument Cluster	V	V																		V	V																																			
L	2013	Equinox	Body	Radio	V	V																		V	V																																			
L	2013	Equinox	Body	Rear Audio Control Module	V	V																		V	V																																			
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
L	2013	Equinox	Body	Liftgate Control Module	V	V																			V																						V													
L	2013	Equinox	Body	Front Seat Heating Control Module	V	V																		V	V																																			
L	2013	Equinox	Body	Right Side Object Detection Control Module	V																			V	V																																			
L	2013	Equinox	Body	Left Side Object Detection Control Module	V																			V	V																																			
L	2013	Equinox	Body	Parking Assist Control Module	V																			V	V																																			
L	2013	Equinox	Body	Frontview Camera Module	V	V																		V	V																																			
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module	V																			V	V	V	V	V	V	V	V	V	V																											
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																			
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module	V	V																		V	V																													V					
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
L	2014	Captiva (3GN)	Body	Body Control Module	V	V																		V	V																																			
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
L	2014	Captiva (3GN)	Body	Passenger Presence Module	V	V																			V																																			
L	2014	Captiva (3GN)	Body	Instrument Cluster	V	V														V				V	V																																			
L	2014	Captiva (3GN)	Body	Radio	V	V																		V	V																																			
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module		V																			V																																			
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
L	2014	Captiva (3GN)	Body	HVAC Control Module	V	V																		V	V																																			
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
L	2014	Captiva (3GN)	Body	Parking Assist Control Module	V	V																		V	V																																			
L	2014	Captiva (3GN)	Body	Theft Deterrent Module	V	V																			V																																			
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																													
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V													V															
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission	V																			V	V			V			V																												
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission	V																			V	V			V			V													V															
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																											
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V															
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																											
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V															
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V														
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V								V	V	V	V	V	V														
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V										V	V	V	V	V																				
L	2014	Captiva (Other)	Powertrain	Chassis Control Module	V	V																		V	V							V		V																										
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module	V	V																		V	V																											V						V
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto	V	V																		V	V																																		
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual	V	V																		V	V																																		
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module	V	V																		V	V																																		
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
L	2014	Captiva (Other)	Body	Instrument Cluster	V	V																		V	V																																		
L	2014	Captiva (Other)	Body	Headlamp Control Module	V	V																		V	V																																		
L	2014	Captiva (Other)	Body	HVAC Control Module	V																			V	V																																		
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)	V	V																		V	V																																		
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)	V	V																		V	V																																		
L	2014	Captiva (Other)	Body	Theft Deterrent Module	V	V																			V																																		
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V																											
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V										V	V	V	V	V																				
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V														
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V							V														
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																		
L	2014	Equinox	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
L	2014	Equinox	Chassis	Power Steering Control Module	V	V																			V																																		
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																		
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																		
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
L	2014	Equinox	Body	Passenger Presence Module	V	V																			V																																		
L	2014	Equinox	Body	Instrument Cluster	V	V																		V	V																																		
L	2014	Equinox	Body	Radio	V	V																		V	V																																		
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2014	Equinox	Body	Liftgate Control Module	V	V																			V																					V													
L	2014	Equinox	Body	Right Side Object Detection Control Module	V																			V	V																																		
L	2014	Equinox	Body	Left Side Object Detection Control Module	V																			V	V																																		
L	2014	Equinox	Body	Parking Assist Control Module	V																			V	V																																		
L	2014	Equinox	Body	Frontview Camera Module	V	V																		V	V																																		
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V													V													
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V													
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
L	2015	Captiva (3GN)	Body	Body Control Module	V	V																		V	V																																		
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
L	2015	Captiva (3GN)	Body	Passenger Presence Module	V	V																			V																																		
L	2015	Captiva (3GN)	Body	Instrument Cluster	V	V														V				V	V																																		
L	2015	Captiva (3GN)	Body	Radio	V	V																		V	V																																		
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module		V																			V																																		
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
L	2015	Captiva (3GN)	Body	HVAC Control Module	V	V																		V	V																																		
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module	V	V																			V																																		
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
L	2015	Captiva (3GN)	Body	Parking Assist Control Module	V	V																		V	V																																		
L	2015	Captiva (3GN)	Body	Theft Deterrent Module	V	V																			V																																		
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																												
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V													V														
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission	V																			V	V			V			V																												
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission	V																			V	V			V			V													V														
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V														
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V													
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2015	Captiva (Other)	Powertrain	Chassis Control Module	V	V																		V	V							V		V																								
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module	V	V																		V	V																												V					V
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto	V	V																		V	V																																		
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual	V	V																		V	V																																		
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module	V	V																		V	V																																		
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
L	2015	Captiva (Other)	Body	Instrument Cluster	V	V																		V	V																																		
L	2015	Captiva (Other)	Body	Headlamp Control Module	V	V																		V	V																																		
L	2015	Captiva (Other)	Body	HVAC Control Module	V																			V	V																																		
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)	V	V																		V	V																																			
L	2015	Captiva (Other)	Body	Theft Deterrent Module	V	V																			V																																			
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V																											
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V															
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V										V														
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																			
L	2015	Equinox	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
L	2015	Equinox	Chassis	Power Steering Control Module	V	V																			V																																			
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																			
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																			
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
L	2015	Equinox	Body	Passenger Presence Module	V	V																			V																																			
L	2015	Equinox	Body	Instrument Cluster	V	V																		V	V																																			
L	2015	Equinox	Body	Radio	V	V																		V	V																																			
L	2015	Equinox	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
L	2015	Equinox	Body	Liftgate Control Module	V	V																			V																					V														
L	2015	Equinox	Body	Right Side Object Detection Control Module	V																			V	V																																			
L	2015	Equinox	Body	Left Side Object Detection Control Module	V																			V	V																																			
L	2015	Equinox	Body	Parking Assist Control Module	V																			V	V																																			
L	2015	Equinox	Body	Frontview Camera Module	V	V																		V	V																																			
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module	V																			V	V	V	V	V	V	V	V	V	V											V																	
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V																
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																						
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module	V	V																		V	V																												V							
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V				
L	2016	Captiva (3GN)	Body	Body Control Module	V	V																		V	V																																			
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
L	2016	Captiva (3GN)	Body	Instrument Cluster	V	V														V				V	V																																			
L	2016	Captiva (3GN)	Body	Radio	V	V																		V	V																																			
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
L	2016	Captiva (3GN)	Body	HVAC Control Module	V	V																		V	V																																			
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module	V	V																			V																																			
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
L	2016	Captiva (3GN)	Body	Parking Assist Control Module	V																			V	V																																			
L	2016	Captiva (3GN)	Body	Theft Deterrent Module	V	V																			V																																			
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission	V																			V	V					V																														
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission	V																			V	V					V																														
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module	V	V																		V	V									V			V																							
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V		V											V																			
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V		V											V																			
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission	V																			V	V			V		V											V																			
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission	V																			V	V			V		V											V																			
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission	V																		V	V	V	V	V	V	V	V																													
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission	V																		V	V	V	V	V	V	V	V													V																
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module	V	V																	V	V									V	V	V	V	V	V																					
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V							V	V	V	V		V														
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission	V																		V	V				V	V	V	V								V	V	V	V	V	V														
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
L	2016	Captiva (Other)	Powertrain	Chassis Control Module	V	V																	V	V							V		V																									
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module	V	V																	V	V																																		
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module	V	V																	V	V																												V					V
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module	V	V																		V																					V							V	V	V	V		
L	2016	Captiva (Other)	Chassis	Power Steering Control Module	V	V																		V																																	
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto	V	V																	V	V																																	
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual	V	V																	V	V																																	
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module	V	V																	V	V																																	
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																	
L	2016	Captiva (Other)	Body	Instrument Cluster	V	V																	V	V																																	
L	2016	Captiva (Other)	Body	Headlamp Control Module	V	V																	V	V																																	
L	2016	Captiva (Other)	Body	Radio	V	V																	V	V																																	
L	2016	Captiva (Other)	Body	HVAC Control Module	V																		V	V																																	
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module	V																		V	V																																	
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module	V																		V	V																																	
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)	V	V																	V	V																																	
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)	V	V																	V	V																																	
L	2016	Captiva (Other)	Body	Theft Deterrent Module	V	V																		V																																	
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																									
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																			
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module	V																		V	V				V	V	V	V	V							V	V	V	V		V														
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																	V	V										V	V	V	V								V													
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module	V	V																		V																																	
L	2016	Equinox	Chassis	Electronic Brake Control Module	V	V																	V	V													V									V	V	V	V	V	V						V
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V
L	2016	Equinox	Chassis	Power Steering Control Module	V	V																		V																																	
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate	V	V																	V	V																																	
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)	V	V																	V	V																																	
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																	
L	2016	Equinox	Body	Passenger Presence Module	V	V																		V																																	
L	2016	Equinox	Body	Instrument Cluster	V	V																	V	V																																	
L	2016	Equinox	Body	Radio	V	V																	V	V																																	
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7	V	V																	V	V																																	
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																	
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)	V	V																	V	V																																	
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)	V	V																	V	V																																	
L	2016	Equinox	Body	Liftgate Control Module	V	V																	V	V																					V													
L	2016	Equinox	Body	Seat Memory Control Module	V																																																			
L	2016	Equinox	Body	Right Side Object Detection Control Module	V																		V	V																																	
L	2016	Equinox	Body	Left Side Object Detection Control Module	V																		V	V																																	
L	2016	Equinox	Body	Parking Assist Control Module	V																		V	V																																	
L	2016	Equinox	Body	Frontview Camera Module	V	V																	V	V																																	
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V												V													
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
M	2004	ALL	Chassis	4WAL 3 Sensor	V	V																		V																																				
M	2004	ALL	Body	Body Control Module	V	V																		V																																			
M	2004	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
M	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V													
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
M	2005	ALL	Chassis	4WAL 3 Sensor	V	V																		V																																			
M	2005	ALL	Body	Body Control Module	V	V																		V																																			
M	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
M	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module	V	V										V					V			V							V													V													
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module	V	V										V					V			V							V													V													
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module	V	V										V					V			V							V													V													
P	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
P	2007	ALL	Body	Theft Deterrent Module	V	V																																																				
R	2009	ALL	Powertrain	Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V															V	V	V	V															
R	2009	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																		
R	2009	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																						
R	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
R	2009	ALL	Body	Body Control Module	V	V																		V	V																																		
R	2009	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
R	2009	ALL	Body	Driver Door Switch	V	V																		V	V																																		
R	2009	ALL	Body	Heated Seat Module	V	V																			V																																		
R	2009	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																		
R	2009	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																		
R	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
R	2009	ALL	Body	Lift Gate Module	V	V																		V	V																																		
R	2009	ALL	Body	Park Assist Module	V	V																		V	V																																		
R	2009	ALL	Body	Passenger Door Switch	V	V																		V	V																																		
R	2009	ALL	Body	Passenger Presence System	V	V																			V																																		
R	2009	ALL	Body	Radio	V	V																		V	V																																		
R	2009	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																		
R	2009	ALL	Body	Rollover Sensor	V	V																			V																																		
R	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
R	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																		
R	2010	ALL	Powertrain	Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V								V								V	V	V	V															
R	2010	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																		
R	2010	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																						
R	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
R	2010	ALL	Body	Body Control Module	V	V																		V	V																																		
R	2010	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
R	2010	ALL	Body	Driver Door Switch	V	V																		V	V																																		
R	2010	ALL	Body	Heated Seat Module	V	V																			V																																		
R	2010	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																		
R	2010	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																		
R	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
R	2010	ALL	Body	Lift Gate Module	V	V																		V	V																																		
R	2010	ALL	Body	Park Assist Module	V	V																			V																																		
R	2010	ALL	Body	Passenger Door Switch	V	V																		V	V																																		
R	2010	ALL	Body	Passenger Presence System	V	V																			V																																		
R	2010	ALL	Body	Radio	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2010	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
R	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
R	2010	ALL	Body	Theft Deterrent Module	V	V																			V																																			
R	2011	ALL	Powertrain	Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V																
R	2011	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
R	2011	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
R	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
R	2011	ALL	Body	Body Control Module	V	V																		V	V																																			
R	2011	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
R	2011	ALL	Body	Driver Door Switch	V	V																		V	V																																			
R	2011	ALL	Body	Heated Seat Module	V	V																			V																																			
R	2011	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
R	2011	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
R	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
R	2011	ALL	Body	Lift Gate Module	V	V																		V	V																																			
R	2011	ALL	Body	Park Assist Module	V	V																			V																																			
R	2011	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
R	2011	ALL	Body	Passenger Presence System	V	V																			V																																			
R	2011	ALL	Body	Radio	V	V																		V	V																																			
R	2011	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
R	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
R	2011	ALL	Body	Theft Deterrent Module	V	V																			V																																			
R	2012	ALL	Powertrain	Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V														
R	2012	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
R	2012	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
R	2012	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		V	
R	2012	ALL	Body	Body Control Module	V	V																		V	V																																			
R	2012	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
R	2012	ALL	Body	Driver Door Switch	V	V																		V	V																																			
R	2012	ALL	Body	Heated Seat Module	V	V																			V																																			
R	2012	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
R	2012	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
R	2012	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
R	2012	ALL	Body	Lift Gate Module	V	V																		V	V																																			
R	2012	ALL	Body	Park Assist Module	V	V																			V																																			
R	2012	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
R	2012	ALL	Body	Passenger Presence System	V	V																			V																																			
R	2012	ALL	Body	Radio	V	V																		V	V																																			
R	2012	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
R	2012	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
R	2012	ALL	Body	Theft Deterrent Module	V	V																			V																																			
R	2013	ALL	Powertrain	Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V														
R	2013	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
R	2013	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
R	2013	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		V	
R	2013	ALL	Body	Body Control Module	V	V																		V	V																																			
R	2013	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
R	2013	ALL	Body	Driver Door Switch	V	V																		V	V																																			
R	2013	ALL	Body	Heated Seat Module	V	V																			V																																			
R	2013	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
R	2013	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2013	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
R	2013	ALL	Body	Left Side Object Detection Module	V																			V	V																																			
R	2013	ALL	Body	Lift Gate Module	V	V																		V	V																																			
R	2013	ALL	Body	Park Assist Module	V	V																			V																																			
R	2013	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
R	2013	ALL	Body	Passenger Presence System	V	V																			V																																			
R	2013	ALL	Body	Radio	V	V																		V	V																																			
R	2013	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
R	2013	ALL	Body	Right Side Object Detection Module	V																			V	V																																			
R	2013	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																			
R	2013	ALL	Body	Theft Deterrent Module	V	V																			V																																			
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V														
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V									V	V	V	V									V													
R	2014	Traverse	Powertrain	Chassis Control Module	V	V																		V	V							V		V																										
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																			
R	2014	Traverse	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																			
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																			
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
R	2014	Traverse	Body	Passenger Presence Module	V	V																			V																																			
R	2014	Traverse	Body	Instrument Cluster	V	V																		V	V																																			
R	2014	Traverse	Body	Radio	V	V																		V	V																																			
R	2014	Traverse	Body	Rear Audio Control Module	V	V																			V																																			
R	2014	Traverse	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
R	2014	Traverse	Body	Personal Audio Link Control Module	V																				V																																			
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
R	2014	Traverse	Body	Driver Door Switch Panel Control Module	V	V																		V	V																					V													
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																			
R	2014	Traverse	Body	Liftgate Control Module	V	V																			V																					V														
R	2014	Traverse	Body	Seat Memory Control Module	V	V																		V	V																																			
R	2014	Traverse	Body	Front Seat Heating Control Module	V	V																			V																																			
R	2014	Traverse	Body	Right Side Object Detection Control Module	V																			V	V																																			
R	2014	Traverse	Body	Left Side Object Detection Control Module	V																			V	V																																			
R	2014	Traverse	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
R	2014	Traverse	Body	Parking Assist Control Module	V																			V	V																																			
R	2014	Traverse	Body	Frontview Camera Module	V	V																		V	V																																			
R	2014	Traverse	Body	Theft Deterrent Module	V	V																			V																																			
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V														
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V									V	V	V	V									V													
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																			
R	2015	Traverse	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																			
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																			
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
R	2015	Traverse	Body	Passenger Presence Module	V	V																			V																																			
R	2015	Traverse	Body	Instrument Cluster	V	V																		V	V																																			
R	2015	Traverse	Body	Radio	V	V																		V	V																																			
R	2015	Traverse	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
R	2015	Traverse	Body	Liftgate Control Module	V	V																			V																					V														
R	2015	Traverse	Body	Seat Memory Control Module	V	V																		V	V																																			
R	2015	Traverse	Body	Front Seat Heating Control Module	V	V																			V																																			
R	2015	Traverse	Body	Right Side Object Detection Control Module	V																			V	V																																			
R	2015	Traverse	Body	Left Side Object Detection Control Module	V																			V	V																																			
R	2015	Traverse	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
R	2015	Traverse	Body	Parking Assist Control Module	V																			V	V																																			
R	2015	Traverse	Body	Frontview Camera Module	V	V																		V	V																																			
R	2015	Traverse	Body	Theft Deterrent Module	V	V																			V																																			
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V		V															
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V									V	V	V	V								V														
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																			
R	2016	Traverse	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V					V
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																			
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																			
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
R	2016	Traverse	Body	Passenger Presence Module	V	V																			V																																			
R	2016	Traverse	Body	Instrument Cluster	V	V																		V	V																																			
R	2016	Traverse	Body	Radio	V	V																		V	V																																			
R	2016	Traverse	Body	Rear Audio Control Module		V																			V																																			
R	2016	Traverse	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
R	2016	Traverse	Body	Personal Audio Link Control Module	V																				V																																			
R	2016	Traverse	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
R	2016	Traverse	Body	Driver Door Switch Panel Control Module	V	V																		V	V																				V															
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																			
R	2016	Traverse	Body	Liftgate Control Module	V	V																			V																				V															
R	2016	Traverse	Body	Seat Memory Control Module	V	V																		V	V																																			
R	2016	Traverse	Body	Front Seat Heating Control Module	V	V																			V																																			
R	2016	Traverse	Body	Right Side Object Detection Control Module	V																			V	V																																			
R	2016	Traverse	Body	Left Side Object Detection Control Module	V																			V	V																																			
R	2016	Traverse	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
R	2016	Traverse	Body	Parking Assist Control Module	V																			V	V																																			
R	2016	Traverse	Body	Frontview Camera Module	V	V																		V	V																																			
R	2016	Traverse	Body	Theft Deterrent Module	V	V																			V																																			
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V			V			V	V							V												V																	
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
S	2004	S10	Chassis	4WAL 3 Sensor	V	V																		V																																				
S	2004	S10	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
S	2004	S10	Body	Body Control Module	V	V																		V																																				
S	2004	S10	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2004	S10	Body	Base Radio	V	V																			V																																			
S	2004	S10	Body	Uplevel Radio	V	V																			V																																			
S	2004	S10	Body	Supplemental Inflatable Restraint	V	V																																																						
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module	V	V						V			V					V	V		V	V							V												V																	
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module	V	V																		V										V	V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module	V	V						V			V					V	V		V	V							V													V														
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module	V	V																	V										V	V																								
S	2004	Colorado	Chassis	ABS Without Traction Control	V	V																	V	V																																		
S	2004	Colorado	Chassis	ABS With Traction Control	V	V																	V	V																																		
S	2004	Colorado	Body	Body Control Module	V	V																	V	V																																		
S	2004	Colorado	Body	Instrument Panel Cluster	V	V																	V	V																																		
S	2004	Colorado	Body	OnStar	V	V																	V	V																																		
S	2004	Colorado	Body	Base Radio	V	V																		V																																		
S	2004	Colorado	Body	Uplevel Radio	V	V																		V																																		
S	2004	Colorado	Body	Supplemental Inflatable Restraint	V	V																																																				
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V						V			V					V	V		V	V							V													V														
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																	V										V	V																								
S	2004	TrailBlazer	Chassis	ABS Without Traction Control	V	V																	V	V																																		
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																	V																																		
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)	V	V																	V																																		
S	2004	TrailBlazer	Body	Amplifier (Bose)	V	V																		V																																		
S	2004	TrailBlazer	Body	Body Control Module	V																																																				
S	2004	TrailBlazer	Body	Driver Door Module	V	V																	V	V																																		
S	2004	TrailBlazer	Body	Driver Seat Module	V	V																	V	V																																		
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto	V	V																	V	V																																		
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual	V	V																	V	V																																		
S	2004	TrailBlazer	Body	Instrument Panel Cluster	V	V																	V	V																																		
S	2004	TrailBlazer	Body	Lift Gate Module	V	V																	V	V																																		
S	2004	TrailBlazer	Body	OnStar	V	V																	V	V																																		
S	2004	TrailBlazer	Body	Passenger Door Module	V	V																	V	V																																		
S	2004	TrailBlazer	Body	Uplevel Radio	V	V																		V																																		
S	2004	TrailBlazer	Body	Navigation Radio	V	V																	V																																		
S	2004	TrailBlazer	Body	Rear Seat Audio	V	V																		V																																		
S	2004	TrailBlazer	Body	Rear Seat Entertainment	V																			V																																		
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint	V	V																																																				
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent	V	V																																																				
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V						V			V					V	V		V	V							V													V														
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																	V										V	V																								
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module	V	V									V	V				V	V		V	V							V													V														
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module	V	V																	V										V	V																								
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control	V	V																	V	V																																		
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																	V																																		
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)	V	V																	V																																		
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)	V	V																		V																																		
S	2004	TrailBlazer EXT	Body	Body Control Module	V																																																				
S	2004	TrailBlazer EXT	Body	Driver Door Module	V	V																	V	V																																		
S	2004	TrailBlazer EXT	Body	Driver Seat Module	V	V																	V	V																																		
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto	V	V																	V	V																																		
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual	V	V																	V	V																																		
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster	V	V																	V	V																																		
S	2004	TrailBlazer EXT	Body	Lift Gate Module	V	V																	V	V																																		
S	2004	TrailBlazer EXT	Body	OnStar	V	V																	V	V																																		
S	2004	TrailBlazer EXT	Body	Passenger Door Module	V	V																	V	V																																		
S	2004	TrailBlazer EXT	Body	Uplevel Radio	V	V																		V																																		
S	2004	TrailBlazer EXT	Body	Navigation Radio	V	V																	V																																		
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto	V	V																	V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual	V	V																		V	V																																					
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment	V																				V																																					
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint	V	V																																																							
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent	V	V																																																							
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V															
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																									
S	2004	Blazer	Chassis	4WAL 3 Sensor	V	V																		V																																					
S	2004	Blazer	Chassis	Traction Assist (If Equipped)	V	V																		V																																					
S	2004	Blazer	Body	Body Control Module	V	V																		V																																					
S	2004	Blazer	Body	Heating and Air Conditioning	V	V																		V	V																																					
S	2004	Blazer	Body	Instrument Panel Cluster	V	V																		V	V																																					
S	2004	Blazer	Body	Memory Seat Module	V	V																			V																																					
S	2004	Blazer	Body	Base Radio	V	V																			V																																					
S	2004	Blazer	Body	Uplevel Radio	V	V																			V																																					
S	2004	Blazer	Body	Supplemental Inflatable Restraint	V	V																																																							
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module	V	V										V	V				V	V		V	V							V													V															
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module	V	V																		V											V	V																									
S	2004	SSR	Chassis	4WAL 3 Sensor	V	V																		V																																					
S	2004	SSR	Chassis	Traction Assist (If Equipped)	V	V																		V																																					
S	2004	SSR	Body	Amplifier (Bose)	V	V																			V																																					
S	2004	SSR	Body	Body Control Module	V	V																		V	V																																					
S	2004	SSR	Body	Driver Seat Module	V	V																		V	V																																					
S	2004	SSR	Body	Instrument Panel Cluster	V	V																		V	V																																					
S	2004	SSR	Body	Uplevel Radio	V	V																			V																																					
S	2004	SSR	Body	Remote Function Actuation	V	V																																																							
S	2004	SSR	Body	Roof and Door Module	V	V																		V	V																																					
S	2004	SSR	Body	Supplemental Inflatable Restraint	V	V																																																							
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module	V	V							V			V					V	V		V	V							V													V															
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module	V	V																		V											V	V																									
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module	V	V							V			V					V	V		V	V							V													V															
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module	V	V																		V											V	V																									
S	2005	Colorado	Chassis	ABS Without Traction Control	V	V																		V	V																																					
S	2005	Colorado	Chassis	ABS With Traction Control	V	V																		V	V																																					
S	2005	Colorado	Body	Body Control Module	V	V																		V	V																																					
S	2005	Colorado	Body	Instrument Panel Cluster	V	V																		V	V																																					
S	2005	Colorado	Body	Base Radio	V	V																			V																																					
S	2005	Colorado	Body	Uplevel Radio	V	V																			V																																					
S	2005	Colorado	Body	Supplemental Inflatable Restraint	V	V																																																							
S	2005	Colorado	Body	Vehicle Comm. Interface Module	V	V																		V	V																																					
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V													V															
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																									
S	2005	TrailBlazer	Chassis	ABS Without Traction Control	V	V																		V	V																																					
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																					
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)	V	V																		V																																					
S	2005	TrailBlazer	Body	Body Control Module	V																																																								
S	2005	TrailBlazer	Body	Disc Player and Video Display	V																				V																																					
S	2005	TrailBlazer	Body	Driver Door Module	V	V																		V	V																																					
S	2005	TrailBlazer	Body	Driver Seat Module	V	V																		V	V																																					
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto	V	V																		V	V																																					
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual	V	V																		V	V																																					
S	2005	TrailBlazer	Body	Instrument Panel Cluster	V	V																		V	V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2005	TrailBlazer	Body	Lift Gate Module	V	V																		V	V																																					
S	2005	TrailBlazer	Body	Passenger Door Module	V	V																		V	V																																					
S	2005	TrailBlazer	Body	Passenger Presence System																																																										
S	2005	TrailBlazer	Body	Uplevel Radio	V	V																			V																																					
S	2005	TrailBlazer	Body	Navigation Radio	V	V																		V																																					
S	2005	TrailBlazer	Body	Rear Seat Audio	V	V																			V																																					
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint	V	V																			V																																					
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module	V	V																		V	V																																					
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent	V	V																																																							
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V						V														V															
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																									
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V						V														V															
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																									
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control	V	V																		V	V																																				
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																					
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)	V	V																		V																																					
S	2005	TrailBlazer EXT	Body	Body Control Module	V																																																								
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display	V																				V																																					
S	2005	TrailBlazer EXT	Body	Driver Door Module	V	V																		V	V																																					
S	2005	TrailBlazer EXT	Body	Driver Seat Module	V	V																		V	V																																					
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto	V	V																		V	V																																					
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual	V	V																		V	V																																					
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster	V	V																		V	V																																					
S	2005	TrailBlazer EXT	Body	Lift Gate Module	V	V																		V	V																																					
S	2005	TrailBlazer EXT	Body	Passenger Door Module	V	V																		V	V																																					
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																										
S	2005	TrailBlazer EXT	Body	Uplevel Radio	V	V																			V																																					
S	2005	TrailBlazer EXT	Body	Navigation Radio	V	V																		V																																					
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto	V	V																		V	V																																					
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual	V	V																		V	V																																					
S	2005	TrailBlazer EXT	Body	Rear Seat Audio	V	V																			V																																					
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint	V	V																			V																																					
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module	V	V																		V	V																																					
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent	V	V																																																							
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V						V														V															
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
S	2005	Blazer	Chassis	4WAL 3 Sensor	V	V																		V																																					
S	2005	Blazer	Chassis	Traction Assist (If Equipped)	V	V																		V																																					
S	2005	Blazer	Body	Body Control Module	V	V																		V																																					
S	2005	Blazer	Body	Heating and Air Conditioning	V	V																		V	V																																					
S	2005	Blazer	Body	Instrument Panel Cluster	V	V																		V	V																																					
S	2005	Blazer	Body	Memory Seat Module	V	V																			V																																					
S	2005	Blazer	Body	Base Radio	V	V																			V																																					
S	2005	Blazer	Body	Uplevel Radio	V	V																			V																																					
S	2005	Blazer	Body	Supplemental Inflatable Restraint	V	V																																																							
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V						V													V															
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																									
S	2005	SSR	Chassis	4WAL 3 Sensor	V	V																		V																																					
S	2005	SSR	Chassis	Traction Assist (If Equipped)	V	V																		V																																					
S	2005	SSR	Body	Amplifier (Bose)	V	V																			V																																					
S	2005	SSR	Body	Body Control Module	V	V																		V	V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2005	SSR	Body	Driver Seat Module	V	V																		V	V																																			
S	2005	SSR	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2005	SSR	Body	Uplevel Radio	V	V																			V																																			
S	2005	SSR	Body	Remote Function Actuation	V	V																																																					
S	2005	SSR	Body	Roof and Door Module	V	V																		V	V																																			
S	2005	SSR	Body	Supplemental Inflatable Restraint	V	V																																																					
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module	V	V																		V											V	V																							
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module	V	V																		V											V	V																							
S	2006	Colorado	Chassis	ABS Without Traction Control	V	V																		V	V																																			
S	2006	Colorado	Chassis	ABS With Traction Control	V	V																		V	V																																			
S	2006	Colorado	Body	Body Control Module	V	V																		V	V																																			
S	2006	Colorado	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2006	Colorado	Body	Passenger Presence System																																																							
S	2006	Colorado	Body	Base Radio	V	V																			V																																			
S	2006	Colorado	Body	Uplevel Radio	V	V																			V																																			
S	2006	Colorado	Body	Supplemental Inflatable Restraint	V	V																																																					
S	2006	Colorado	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																							
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V											V	V																							
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V											V	V																							
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES	V	V																		V	V																																			
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor	V	V																		V																																			
S	2006	TrailBlazer	Body	Body Control Module	V	V																		V	V																																			
S	2006	TrailBlazer	Body	Disc Player and Video Display	V																				V																																			
S	2006	TrailBlazer	Body	Driver Door Module	V	V																		V	V																																			
S	2006	TrailBlazer	Body	Driver Seat Module	V	V																		V	V																																			
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
S	2006	TrailBlazer	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2006	TrailBlazer	Body	Lift Gate Module	V	V																		V	V																																			
S	2006	TrailBlazer	Body	Passenger Door Module	V	V																		V	V																																			
S	2006	TrailBlazer	Body	Passenger Presence System																																																							
S	2006	TrailBlazer	Body	Uplevel Radio	V	V																			V																																			
S	2006	TrailBlazer	Body	Navigation Radio	V	V																		V																																			
S	2006	TrailBlazer	Body	Rear Seat Audio	V	V																			V																																			
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint	V	V																			V																																			
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent	V	V																																																					
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																							
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V											V	V																							
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES	V	V																		V	V																																			
S	2006	TrailBlazer EXT	Body	Body Control Module	V	V																		V	V																																			
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display	V																				V																																			
S	2006	TrailBlazer EXT	Body	Driver Door Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2006	TrailBlazer EXT	Body	Driver Seat Module	V	V																		V	V																																			
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2006	TrailBlazer EXT	Body	Lift Gate Module	V	V																		V	V																																			
S	2006	TrailBlazer EXT	Body	Passenger Door Module	V	V																		V	V																																			
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																								
S	2006	TrailBlazer EXT	Body	Uplevel Radio	V	V																			V																																			
S	2006	TrailBlazer EXT	Body	Navigation Radio	V	V																		V																																			
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto	V	V																		V	V																																			
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual	V	V																		V	V																																			
S	2006	TrailBlazer EXT	Body	Rear Seat Audio	V	V																			V																																			
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint	V	V																			V																																			
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent	V	V																																																					
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V						V														V													
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																								
S	2006	SSR	Chassis	4WAL 3 Sensor	V	V																		V																																			
S	2006	SSR	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
S	2006	SSR	Body	Amplifier (Bose)	V	V																			V																																			
S	2006	SSR	Body	Body Control Module	V	V																		V	V																																			
S	2006	SSR	Body	Driver Seat Module	V	V																		V	V																																			
S	2006	SSR	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2006	SSR	Body	Uplevel Radio	V	V																			V																																			
S	2006	SSR	Body	Remote Function Actuation	V	V																																																					
S	2006	SSR	Body	Roof and Door Module	V	V																		V	V																																			
S	2006	SSR	Body	Supplemental Inflatable Restraint	V	V																																																					
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V						V			V	V	V			V	V		V							V														V													
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																								
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V						V			V	V	V			V	V		V							V														V													
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control	V	V																		V	V																																			
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control	V	V																		V	V																																			
S	2007	Colorado	Body	Body Control Module	V	V																		V	V																																			
S	2007	Colorado	Body	Digital Radio Receiver	V	V																			V																																			
S	2007	Colorado	Body	Generator Battery Control Module	V	V																		V	V																																			
S	2007	Colorado	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2007	Colorado	Body	Passenger Presence System																																																							
S	2007	Colorado	Body	Base Radio	V	V																			V																																			
S	2007	Colorado	Body	Uplevel Radio	V	V																			V																																			
S	2007	Colorado	Body	Supplemental Inflatable Restraint	V	V																																																					
S	2007	Colorado	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V	V						V			V	V	V			V	V		V							V														V													
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																								
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module	V	V	V						V			V	V	V			V	V		V							V														V													
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module	V	V																		V										V	V																								
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V													
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																								
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V													
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																								
S	2007	Trailblazer	Chassis	Electronic Brake Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2007	Trailblazer	Body	Body Control Module	V	V																		V	V																																			
S	2007	Trailblazer	Body	Digital Radio Receiver	V	V																			V																																			
S	2007	Trailblazer	Body	Disc Player and Video Display	V																				V																																			
S	2007	Trailblazer	Body	Driver Door Module	V	V																		V	V																																			
S	2007	Trailblazer	Body	Driver Seat Module	V	V																		V	V																																			
S	2007	Trailblazer	Body	Generator Battery Control Module	V	V																		V	V																																			
S	2007	Trailblazer	Body	HVAC Control Module Auto	V	V																		V	V																																			
S	2007	Trailblazer	Body	HVAC Control Module Manual	V	V																		V	V																																			
S	2007	Trailblazer	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2007	Trailblazer	Body	Lift Gate Module	V	V																		V	V																																			
S	2007	Trailblazer	Body	Passenger Door Module	V	V																		V	V																																			
S	2007	Trailblazer	Body	Passenger Presence System																																																								
S	2007	Trailblazer	Body	Uplevel Radio	V	V																			V																																			
S	2007	Trailblazer	Body	Navigation Radio	V	V																		V																																			
S	2007	Trailblazer	Body	Rear Seat Audio	V	V																			V																																			
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint	V	V																			V																																			
S	2007	Trailblazer	Body	Theft Deterrent Module	V	V																																																						
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																									
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																									
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control	V	V																		V	V																																			
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control	V	V																		V	V																																			
S	2008	Colorado	Body	Body Control Module	V	V																		V	V																																			
S	2008	Colorado	Body	Digital Radio Receiver	V	V																			V																																			
S	2008	Colorado	Body	Generator Battery Control Module	V	V																		V	V																																			
S	2008	Colorado	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2008	Colorado	Body	Passenger Presence System																																																							
S	2008	Colorado	Body	Base Radio	V	V																			V																																			
S	2008	Colorado	Body	Uplevel Radio	V	V																			V																																			
S	2008	Colorado	Body	Supplemental Inflatable Restraint	V	V																																																					
S	2008	Colorado	Body	Theft Deterrent Module	V	V																																																					
S	2008	Colorado	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																									
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																									
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																									
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
S	2008	TrailBlazer	Body	Body Control Module	V	V																		V	V																																			
S	2008	TrailBlazer	Body	Digital Radio Receiver	V	V																			V																																			
S	2008	TrailBlazer	Body	Disc Player and Video Display	V																				V																																			
S	2008	TrailBlazer	Body	Driver Door Module	V	V																		V	V																																			
S	2008	TrailBlazer	Body	Driver Seat Module	V	V																		V	V																																			
S	2008	TrailBlazer	Body	Generator Battery Control Module	V	V																		V	V																																			
S	2008	TrailBlazer	Body	HVAC Control Module Auto	V	V																		V	V																																			
S	2008	TrailBlazer	Body	HVAC Control Module Manual	V	V																		V	V																																			
S	2008	TrailBlazer	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2008	TrailBlazer	Body	Lift Gate Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2008	TrailBlazer	Body	Passenger Door Module	V	V																		V	V																																			
S	2008	TrailBlazer	Body	Passenger Presence System																																																								
S	2008	TrailBlazer	Body	Uplevel Radio	V	V																			V																																			
S	2008	TrailBlazer	Body	Navigation Radio	V	V																		V																																			
S	2008	TrailBlazer	Body	Rear Seat Audio	V	V																			V																																		
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint	V	V																			V																																		
S	2008	TrailBlazer	Body	Theft Deterrent Module	V	V																																																					
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																								
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																		
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																		
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module	V	V																		V										V	V																								
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module	V	V																		V	V																																		
S	2009	Colorado	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
S	2009	Colorado	Body	Body Control Module	V	V																		V	V																																		
S	2009	Colorado	Body	Digital Radio Receiver	V	V																		V	V																																		
S	2009	Colorado	Body	Generator Battery Control Module	V	V																		V	V																																		
S	2009	Colorado	Body	Instrument Panel Cluster	V	V																		V	V																																		
S	2009	Colorado	Body	Passenger Presence System																																																							
S	2009	Colorado	Body	Base Radio	V	V																			V																																		
S	2009	Colorado	Body	Uplevel Radio	V	V																			V																																		
S	2009	Colorado	Body	Supplemental Inflatable Restraint	V	V																																																				
S	2009	Colorado	Body	Theft Deterrent Module	V	V																																																				
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																								
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module	V	V																		V	V																																		
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V													
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																								
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																		
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V													
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																								
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module	V	V																		V	V																																		
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
S	2009	TrailBlazer	Body	Body Control Module	V	V																		V	V																																		
S	2009	TrailBlazer	Body	Digital Radio Receiver	V	V																		V	V																																		
S	2009	TrailBlazer	Body	Disc Player and Video Display	V																				V																																		
S	2009	TrailBlazer	Body	Driver Door Module	V	V																		V	V																																		
S	2009	TrailBlazer	Body	Driver Seat Module	V	V																		V	V																																		
S	2009	TrailBlazer	Body	Generator Battery Control Module	V	V																		V	V																																		
S	2009	TrailBlazer	Body	HVAC Control Module Auto	V	V																		V	V																																		
S	2009	TrailBlazer	Body	HVAC Control Module Manual	V	V																		V	V																																		
S	2009	TrailBlazer	Body	Instrument Panel Cluster	V	V																		V	V																																		
S	2009	TrailBlazer	Body	Lift Gate Module	V	V																		V	V																																		
S	2009	TrailBlazer	Body	Passenger Door Module	V	V																		V	V																																		
S	2009	TrailBlazer	Body	Passenger Presence System																																																						
S	2009	TrailBlazer	Body	Uplevel Radio	V	V																			V																																		
S	2009	TrailBlazer	Body	Navigation Radio	V	V																		V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2009	TrailBlazer	Body	Rear Seat Audio	V	V																			V																																			
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint	V	V																			V																																			
S	2009	TrailBlazer	Body	Theft Deterrent Module	V	V																																																						
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																		
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																		
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module	V	V																		V										V	V																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																		
S	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
S	2010	ALL	Body	Body Control Module	V	V																		V	V																																		
S	2010	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
S	2010	ALL	Body	Generator Battery Control Module	V	V																		V	V																																		
S	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
S	2010	ALL	Body	Passenger Presence System																																																						
S	2010	ALL	Body	Personal Audio Link Module	V																				V																																		
S	2010	ALL	Body	Base Radio	V	V																			V																																		
S	2010	ALL	Body	Uplevel Radio	V	V																			V																																		
S	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
S	2010	ALL	Body	Theft Deterrent Module	V	V																																																				
S	2010	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																								
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																		
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																		
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module	V	V																		V										V	V																								
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																		
S	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
S	2011	ALL	Body	Body Control Module	V	V																		V	V																																		
S	2011	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
S	2011	ALL	Body	Generator Battery Control Module	V	V																		V	V																																		
S	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
S	2011	ALL	Body	Passenger Presence System																																																						
S	2011	ALL	Body	Personal Audio Link Module	V																				V																																		
S	2011	ALL	Body	Base Radio	V	V																			V																																		
S	2011	ALL	Body	Uplevel Radio	V	V																			V																																		
S	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
S	2011	ALL	Body	Theft Deterrent Module	V	V																																																				
S	2011	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																								
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																		
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																			V														
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module	V	V																		V										V	V																							
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																	
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module	V	V																		V	V																																	
S	2012	Colorado (First Gen)	Body	Body Control Module	V	V																		V	V																																	
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver	V	V																		V	V																																	
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module	V	V																		V	V																																	
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster	V	V																		V	V																																	
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																						
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module	V																				V																																	
S	2012	Colorado (First Gen)	Body	Base Radio	V	V																			V																																	
S	2012	Colorado (First Gen)	Body	Uplevel Radio	V	V																			V																																	
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint	V	V																																																			
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module	V	V																																																			
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module	V	V																		V	V																																	
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																									
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V																									
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission	V																			V	V						V																										
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission	V																			V	V						V																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission	V																			V	V						V																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission	V																			V	V						V																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module	V	V																		V	V									V	V	V	V								V													
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module	V	V																		V	V									V	V	V	V								V													
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module	V	V																		V	V																																	
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V											
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
S	2012	Colorado (Second Gen)	Body	Body Control Module	V	V																		V	V																																	
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
S	2012	Colorado (Second Gen)	Body	Instrument Cluster	V	V																		V	V																																	
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module	V	V																		V	V																																	
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																									
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V																									
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V													
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V													
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission	V																			V	V						V																										
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission	V																			V	V						V																										
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission	V																			V	V						V																										
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission	V																			V	V						V																										
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module	V	V																		V	V									V	V	V	V								V													
S	2012	S10	Powertrain	Transfer Case Control Module	V	V																		V	V																																	
S	2012	S10	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V											
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
S	2012	S10	Body	Body Control Module	V	V																		V	V																																	
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
S	2012	S10	Body	Instrument Cluster	V	V																		V	V																																	
S	2012	S10	Body	Trailer Interface Control Module	V	V																		V	V																																	
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																									
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission	V																		V	V						V																													
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission	V																		V	V						V																													
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission	V																		V	V						V																													
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission	V																		V	V						V																													
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module	V	V																	V	V										V	V	V	V									V												
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V								V	V	V	V		V												
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V								V	V	V	V	V	V												
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module	V	V																	V	V										V	V	V	V									V												
S	2013	Colorado	Powertrain	Transfer Case Control Module	V	V																	V	V																																		
S	2013	Colorado	Chassis	Electronic Brake Control Module	V	V																	V	V													V											V										
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
S	2013	Colorado	Body	Body Control Module	V	V																	V	V																																		
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
S	2013	Colorado	Body	Instrument Cluster	V	V																	V	V																																		
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V	V																												
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission	V																		V	V			V	V	V	V	V																												
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V														V													
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V														V													
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission	V																		V	V						V																												
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission	V																		V	V						V																												
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission	V																		V	V						V																												
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission	V																		V	V						V																												
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module	V	V																	V	V										V	V	V	V									V												
S	2013	S10	Powertrain	Transfer Case Control Module	V	V																	V	V																																		
S	2013	S10	Chassis	Electronic Brake Control Module	V	V																	V	V													V											V										
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
S	2013	S10	Body	Body Control Module	V	V																	V	V																																		
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
S	2013	S10	Body	Instrument Cluster	V	V																	V	V																																		
S	2013	S10	Body	Trailer Interface Control Module	V	V																	V	V																																		
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission	V																		V	V						V																												
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission	V																		V	V						V																												
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission	V																		V	V						V																												
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission	V																		V	V						V																												
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module	V	V																	V	V										V	V	V	V									V												
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V								V	V	V	V		V												
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																		V	V				V	V	V	V									V	V	V	V	V	V												
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																	V	V										V	V	V	V									V												
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V								V	V	V	V		V												
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V								V	V	V	V	V	V												
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module	V	V																	V	V										V	V	V	V									V												
S	2013	Trailblazer	Powertrain	Transfer Case Control Module	V	V																	V	V																																		
S	2013	Trailblazer	Chassis	Electronic Brake Control Module	V	V																	V	V													V											V										
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
S	2013	Trailblazer	Body	Body Control Module	V	V																	V	V																																		
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
S	2013	Trailblazer	Body	Instrument Cluster	V	V																	V	V																																		
S	2013	Trailblazer	Body	Trailer Interface Control Module	V	V																	V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2013	Trailblazer	Body	Parking Assist Control Module	V																		V	V																																				
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V	V																												
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission	V																		V	V			V	V	V	V	V																												
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																		V	V																																			
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																		V	V																																			
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																		V	V																																			
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																		V	V																																			
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module	V	V																	V	V									V	V	V	V										V													
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V							V	V	V	V		V														
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V							V	V	V	V	V	V														
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module	V	V																	V	V									V	V	V	V									V													
S	2014	Colorado	Powertrain	Transfer Case Control Module	V	V																	V	V																																			
S	2014	Colorado	Chassis	Electronic Brake Control Module	V	V																	V	V												V											V											
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module	V																			V																																		
S	2014	Colorado	Body	Body Control Module	V	V																	V	V																																		
S	2014	Colorado	Body	Body Control Module	V	V																	V	V																																		
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
S	2014	Colorado	Body	Instrument Cluster	V	V																	V	V																																		
S	2014	Colorado	Body	Radio	V	V																	V	V																																		
S	2014	Colorado	Body	Telematics Communication Interface Control Module	V	V																	V	V																																		
S	2014	Colorado	Body	Parking Assist Control Module	V																		V	V																																		
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V	V																												
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission	V																		V	V			V	V	V	V	V																												
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V														
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V														
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																		V	V																																		
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																		V	V																																		
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																		V	V																																		
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																		V	V																																		
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module	V	V																	V	V									V	V	V	V									V													
S	2014	S10	Powertrain	Transfer Case Control Module	V	V																	V	V																																		
S	2014	S10	Chassis	Electronic Brake Control Module	V	V																	V	V												V											V											
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module	V																			V																																		
S	2014	S10	Body	Body Control Module	V	V																	V	V																																		
S	2014	S10	Body	Body Control Module	V	V																	V	V																																		
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
S	2014	S10	Body	Instrument Cluster	V	V																	V	V																																		
S	2014	S10	Body	Trailer Interface Control Module	V	V																	V	V																																		
S	2014	S10	Body	Radio	V	V																	V	V																																		
S	2014	S10	Body	Parking Assist Control Module	V	V																	V	V																																		
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																		V	V																																		
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																		V	V																																		
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																		V	V																																		
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																		V	V																																		
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module	V	V																	V	V									V	V	V	V									V													
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V							V	V	V	V		V														
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V							V	V	V	V	V	V														
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module	V	V																	V	V									V	V	V	V									V													
S	2014	Trailblazer	Powertrain	Transfer Case Control Module	V	V																	V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2014	Trailblazer	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V												
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
S	2014	Trailblazer	Body	Body Control Module	V	V																		V	V																																	
S	2014	Trailblazer	Body	Body Control Module	V	V																		V	V																																	
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
S	2014	Trailblazer	Body	Instrument Cluster	V	V																		V	V																																	
S	2014	Trailblazer	Body	Trailer Interface Control Module	V	V																		V	V																																	
S	2014	Trailblazer	Body	Parking Assist Control Module	V																			V	V																																	
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																									
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V													
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V									V	V	V	V										V											
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																			V	V																																	
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																			V	V																																	
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																			V	V																																	
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																			V	V																																	
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module	V	V																		V	V									V	V	V	V										V											
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V												
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V							V	V	V	V	V	V												
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V										V											
S	2015	Colorado	Powertrain	Chassis Control Module	V	V									V									V	V							V																									
S	2015	Colorado	Powertrain	Transfer Case Control Module	V	V																		V	V																																	
S	2015	Colorado	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V					V
S	2015	Colorado	Chassis	Power Steering Control Module	V	V																			V																																	
S	2015	Colorado	Body	Body Control Module	V	V																		V	V																																	
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
S	2015	Colorado	Body	Passenger Presence Module	V	V																			V																																	
S	2015	Colorado	Body	Radio	V	V																		V	V																																	
S	2015	Colorado	Body	Amplifier	V	V																			V																																	
S	2015	Colorado	Body	Human Machine Interface Control Module	V	V																		V	V																							V										
S	2015	Colorado	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																	
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																	
S	2015	Colorado	Body	Frontview Camera Module	V	V																		V	V																																	
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																									
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V													
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V									V	V	V	V										V											
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																			V	V																																	
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																			V	V																																	
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																			V	V																																	
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																			V	V																																	
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module	V	V																		V	V									V	V	V	V										V											
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V												
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V							V	V	V	V	V	V												
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V										V											
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module	V	V																		V	V																																	
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V										
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
S	2015	Colorado (MMM)	Body	Body Control Module	V	V																		V	V																																	
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2015	Colorado (MMM)	Body	Instrument Cluster	V	V																		V	V																																			
S	2015	Colorado (MMM)	Body	Radio	V	V																		V	V																																			
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
S	2015	Colorado (MMM)	Body	Parking Assist Control Module	V	V																			V																																			
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V	V																										
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V	V											V														
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V										V	V	V	V									V												
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																			V	V																																		
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																			V	V																																		
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																			V	V																																		
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																			V	V																																		
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module	V	V																		V	V										V	V	V	V									V												
S	2015	S10	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
S	2015	S10	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V											
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
S	2015	S10	Body	Body Control Module	V	V																		V	V																																		
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
S	2015	S10	Body	Instrument Cluster	V	V																		V	V																																		
S	2015	S10	Body	Trailer Interface Control Module	V	V																		V	V																																		
S	2015	S10	Body	Radio	V	V																		V	V																																		
S	2015	S10	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
S	2015	S10	Body	Parking Assist Control Module	V	V																			V																																		
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																			V	V																																		
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																			V	V																																		
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																			V	V																																		
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																			V	V																																		
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module	V	V																		V	V										V	V	V	V									V												
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V														
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V							V	V	V	V	V	V														
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V												
S	2015	Trailblazer	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
S	2015	Trailblazer	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V											
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
S	2015	Trailblazer	Body	Body Control Module	V	V																		V	V																																		
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
S	2015	Trailblazer	Body	Instrument Cluster	V	V																		V	V																																		
S	2015	Trailblazer	Body	Trailer Interface Control Module	V	V																		V	V																																		
S	2015	Trailblazer	Body	Radio	V	V																		V	V																																		
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
S	2015	Trailblazer	Body	Parking Assist Control Module	V	V																			V																																		
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V	V																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V	V											V														
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V										V	V	V	V									V												
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module	V																			V	V																																		
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module	V	V																		V	V										V	V	V	V									V												
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V														
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module	V	V																		V	V																																				
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module	V	V																			V																																			
S	2016	Colorado (1GC)	Body	Body Control Module	V	V																		V	V																																			
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
S	2016	Colorado (1GC)	Body	Passenger Presence Module	V	V																			V																																			
S	2016	Colorado (1GC)	Body	Radio Controls	V																				V																																			
S	2016	Colorado (1GC)	Body	HVAC Controls	V																			V	V																																			
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module	V	V																		V	V																																			
S	2016	Colorado (1GC)	Body	Radio	V	V																		V	V																																			
S	2016	Colorado (1GC)	Body	Amplifier	V	V																			V																																			
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
S	2016	Colorado (1GC)	Body	Frontview Camera Module	V	V																		V	V																																			
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V	V																												
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V	V												V															
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																			V	V						V																												
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																			V	V						V																												
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission	V																			V	V						V																												
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission	V																			V	V						V																												
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module	V	V																		V	V									V	V	V	V									V													
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V													
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V											V	
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
S	2016	Colorado (MMM)	Body	Body Control Module	V	V																		V	V																																			
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
S	2016	Colorado (MMM)	Body	Instrument Cluster	V	V																		V	V																																			
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module	V	V																		V	V																																			
S	2016	Colorado (MMM)	Body	Radio	V	V																		V	V																																			
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
S	2016	Colorado (MMM)	Body	Parking Assist Control Module	V																			V	V																																			
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module	V																			V	V				V	V	V	V												V															
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V	V																												
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V	V												V															
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V									V	V	V	V									V													
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission	V																			V	V						V																												
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission	V																			V	V						V																												
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module	V	V																		V	V									V	V	V	V									V													
S	2016	S10	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
S	2016	S10	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V											V	
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
S	2016	S10	Body	Body Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
S	2016	S10	Body	Instrument Cluster	V	V																		V	V																																			
S	2016	S10	Body	Trailer Interface Control Module	V	V																		V	V																																			
S	2016	S10	Body	Radio	V	V																		V	V																																			
S	2016	S10	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
S	2016	S10	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
S	2016	S10	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
S	2016	S10	Body	Parking Assist Control Module	V																			V	V																																			
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																			V	V						V																												
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																			V	V						V																												
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission	V																			V	V						V																												
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission	V																			V	V						V																												
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module	V	V																		V	V									V	V	V	V										V											
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V												
S	2016	Trailblazer	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
S	2016	Trailblazer	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V									V	
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
S	2016	Trailblazer	Body	Body Control Module	V	V																		V	V																																			
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
S	2016	Trailblazer	Body	Instrument Cluster	V	V																		V	V																																			
S	2016	Trailblazer	Body	Trailer Interface Control Module	V	V																		V	V																																			
S	2016	Trailblazer	Body	Radio	V	V																		V	V																																			
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
S	2016	Trailblazer	Body	Parking Assist Control Module	V																			V	V																																			
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display	V	V																		V																																			
T	2004	S10	Chassis	4WAL 3 Sensor	V	V																		V																																			
T	2004	S10	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
T	2004	S10	Body	Body Control Module	V	V																		V																																			
T	2004	S10	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2004	S10	Body	Base Radio	V	V																			V																																			
T	2004	S10	Body	Uplevel Radio	V	V																			V																																			
T	2004	S10	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module	V	V																		V										V	V																								
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module	V	V																		V										V	V																								
T	2004	Colorado	Chassis	ABS Without Traction Control	V	V																		V	V																																			
T	2004	Colorado	Chassis	ABS With Traction Control	V	V																		V	V																																			
T	2004	Colorado	Body	Body Control Module	V	V																		V	V																																			
T	2004	Colorado	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2004	Colorado	Body	OnStar	V	V																		V	V																																			
T	2004	Colorado	Body	Base Radio	V	V																			V																																			
T	2004	Colorado	Body	Uplevel Radio	V	V																			V																																			
T	2004	Colorado	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2004	Colorado	Body	Instrument Panel Cluster	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V													V														
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																							
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active	V	V																		V																																			
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable	V	V																		V																																			
T	2004	TrailBlazer	Chassis	ABS Without Traction Control	V	V																		V	V																																		
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																			
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
T	2004	TrailBlazer	Body	Amplifier (Bose)	V	V																			V																																			
T	2004	TrailBlazer	Body	Body Control Module	V																																																						
T	2004	TrailBlazer	Body	Driver Door Module	V	V																		V	V																																		
T	2004	TrailBlazer	Body	Driver Seat Module	V	V																		V	V																																		
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto	V	V																		V	V																																		
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual	V	V																		V	V																																		
T	2004	TrailBlazer	Body	Instrument Panel Cluster	V	V																		V	V																																		
T	2004	TrailBlazer	Body	Lift Gate Module	V	V																		V	V																																		
T	2004	TrailBlazer	Body	OnStar	V	V																		V	V																																		
T	2004	TrailBlazer	Body	Passenger Door Module	V	V																		V	V																																		
T	2004	TrailBlazer	Body	Uplevel Radio	V	V																			V																																		
T	2004	TrailBlazer	Body	Navigation Radio	V	V																		V																																		
T	2004	TrailBlazer	Body	Rear Seat Audio	V	V																			V																																		
T	2004	TrailBlazer	Body	Rear Seat Entertainment	V																				V																																		
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint	V	V																																																				
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent	V	V																																																				
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V													V														
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																							
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display	V	V																		V																																			
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module	V	V																		V											V	V																							
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display	V	V																		V																																			
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control	V	V																		V	V																																		
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																			
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)	V	V																			V																																		
T	2004	TrailBlazer EXT	Body	Body Control Module	V																																																					
T	2004	TrailBlazer EXT	Body	Driver Door Module	V	V																		V	V																																		
T	2004	TrailBlazer EXT	Body	Driver Seat Module	V	V																		V	V																																		
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto	V	V																		V	V																																		
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual	V	V																		V	V																																		
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster	V	V																		V	V																																		
T	2004	TrailBlazer EXT	Body	Lift Gate Module	V	V																		V	V																																		
T	2004	TrailBlazer EXT	Body	OnStar	V	V																		V	V																																		
T	2004	TrailBlazer EXT	Body	Passenger Door Module	V	V																		V	V																																		
T	2004	TrailBlazer EXT	Body	Uplevel Radio	V	V																			V																																		
T	2004	TrailBlazer EXT	Body	Navigation Radio	V	V																		V																																		
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto	V	V																		V	V																																		
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual	V	V																		V	V																																		
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment	V																				V																																		
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint	V	V																																																				
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent	V	V																																																				
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V														
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display	V	V																		V																																				
T	2004	Blazer	Chassis	4WAL 3 Sensor	V	V																		V																																				
T	2004	Blazer	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
T	2004	Blazer	Body	Body Control Module	V	V																		V																																				
T	2004	Blazer	Body	Heating and Air Conditioning	V	V																		V	V																																			
T	2004	Blazer	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2004	Blazer	Body	Memory Seat Module	V	V																			V																																			
T	2004	Blazer	Body	Base Radio	V	V																			V																																			
T	2004	Blazer	Body	Uplevel Radio	V	V																			V																																			
T	2004	Blazer	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module	V	V							V			V					V	V		V	V						V														V													
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module	V	V																		V										V	V																								
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module	V	V							V			V					V	V		V	V						V														V													
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module	V	V																		V										V	V																								
T	2005	Colorado	Chassis	ABS Without Traction Control	V	V																		V	V																																			
T	2005	Colorado	Chassis	ABS With Traction Control	V	V																		V	V																																			
T	2005	Colorado	Body	Body Control Module	V	V																		V	V																																			
T	2005	Colorado	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2005	Colorado	Body	Base Radio	V	V																			V																																			
T	2005	Colorado	Body	Uplevel Radio	V	V																			V																																			
T	2005	Colorado	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2005	Colorado	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V						V														V													
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																								
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active	V	V																		V																																				
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable	V	V										V	V				V			V	V						V														V													
T	2005	TrailBlazer	Chassis	ABS Without Traction Control	V	V																		V	V																																			
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																				
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
T	2005	TrailBlazer	Body	Body Control Module	V																																																						
T	2005	TrailBlazer	Body	Disc Player and Video Display	V																				V																																			
T	2005	TrailBlazer	Body	Driver Door Module	V	V																		V	V																																			
T	2005	TrailBlazer	Body	Driver Seat Module	V	V																		V	V																																			
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
T	2005	TrailBlazer	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2005	TrailBlazer	Body	Lift Gate Module	V	V																		V	V																																			
T	2005	TrailBlazer	Body	Passenger Door Module	V	V																		V	V																																			
T	2005	TrailBlazer	Body	Passenger Presence System																																																								
T	2005	TrailBlazer	Body	Uplevel Radio	V	V																			V																																			
T	2005	TrailBlazer	Body	Navigation Radio	V	V																		V																																				
T	2005	TrailBlazer	Body	Rear Seat Audio	V	V																			V																																			
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint	V	V																			V																																			
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent	V	V																																																					
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V						V														V													
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																								
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display	V	V																		V																																			
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V						V														V													
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																								
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display	V	V																		V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control	V	V																		V	V																																			
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																			
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
T	2005	TrailBlazer EXT	Body	Body Control Module	V																																																						
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display	V																				V																																		
T	2005	TrailBlazer EXT	Body	Driver Door Module	V	V																		V	V																																		
T	2005	TrailBlazer EXT	Body	Driver Seat Module	V	V																		V	V																																		
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto	V	V																		V	V																																		
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual	V	V																		V	V																																		
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster	V	V																		V	V																																		
T	2005	TrailBlazer EXT	Body	Lift Gate Module	V	V																		V	V																																		
T	2005	TrailBlazer EXT	Body	Passenger Door Module	V	V																		V	V																																		
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																							
T	2005	TrailBlazer EXT	Body	Uplevel Radio	V	V																			V																																		
T	2005	TrailBlazer EXT	Body	Navigation Radio	V	V																		V																																			
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto	V	V																		V	V																																		
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual	V	V																		V	V																																		
T	2005	TrailBlazer EXT	Body	Rear Seat Audio	V	V																			V																																		
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint	V	V																			V																																		
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent	V	V																																																				
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V													
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																						
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display	V	V																		V																																		
T	2005	Blazer	Chassis	4WAL 3 Sensor	V	V																		V																																		
T	2005	Blazer	Chassis	Traction Assist (If Equipped)	V	V																		V																																		
T	2005	Blazer	Body	Body Control Module	V	V																		V																																		
T	2005	Blazer	Body	Heating and Air Conditioning	V	V																		V	V																																		
T	2005	Blazer	Body	Instrument Panel Cluster	V	V																		V	V																																		
T	2005	Blazer	Body	Memory Seat Module	V	V																			V																																		
T	2005	Blazer	Body	Base Radio	V	V																			V																																		
T	2005	Blazer	Body	Uplevel Radio	V	V																			V																																		
T	2005	Blazer	Body	Supplemental Inflatable Restraint	V	V																																																				
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module	V	V							V			V					V	V		V	V							V													V													
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module	V	V																		V											V	V																						
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module	V	V							V			V					V	V		V	V							V													V													
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module	V	V																		V											V	V																						
T	2006	Colorado	Chassis	ABS Without Traction Control	V	V																		V	V																																		
T	2006	Colorado	Chassis	ABS With Traction Control	V	V																		V	V																																		
T	2006	Colorado	Body	Body Control Module	V	V																		V	V																																		
T	2006	Colorado	Body	Instrument Panel Cluster	V	V																		V	V																																		
T	2006	Colorado	Body	Passenger Presence System																																																						
T	2006	Colorado	Body	Base Radio	V	V																			V																																		
T	2006	Colorado	Body	Uplevel Radio	V	V																			V																																		
T	2006	Colorado	Body	Supplemental Inflatable Restraint	V	V																																																				
T	2006	Colorado	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V													V													
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																						
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display	V	V																		V																																		
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V													
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V											V	V																						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display	V	V																		V																																					
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																									
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES	V	V																		V	V																																			
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor	V	V																		V																																				
T	2006	TrailBlazer	Body	Body Control Module	V	V																		V	V																																			
T	2006	TrailBlazer	Body	Disc Player and Video Display	V																				V																																			
T	2006	TrailBlazer	Body	Driver Door Module	V	V																		V	V																																			
T	2006	TrailBlazer	Body	Driver Seat Module	V	V																		V	V																																			
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
T	2006	TrailBlazer	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2006	TrailBlazer	Body	Lift Gate Module	V	V																		V	V																																			
T	2006	TrailBlazer	Body	Passenger Door Module	V	V																		V	V																																			
T	2006	TrailBlazer	Body	Passenger Presence System																																																								
T	2006	TrailBlazer	Body	Uplevel Radio	V	V																			V																																			
T	2006	TrailBlazer	Body	Navigation Radio	V	V																		V																																				
T	2006	TrailBlazer	Body	Rear Seat Audio	V	V																			V																																			
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint	V	V																			V																																			
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent	V	V																																																					
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V													V														
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display	V	V																		V																																			
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display	V	V																		V																																			
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES	V	V																		V	V																																			
T	2006	TrailBlazer EXT	Body	Body Control Module	V	V																		V	V																																			
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display	V																				V																																			
T	2006	TrailBlazer EXT	Body	Driver Door Module	V	V																		V	V																																			
T	2006	TrailBlazer EXT	Body	Driver Seat Module	V	V																		V	V																																			
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2006	TrailBlazer EXT	Body	Lift Gate Module	V	V																		V	V																																			
T	2006	TrailBlazer EXT	Body	Passenger Door Module	V	V																		V	V																																			
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																								
T	2006	TrailBlazer EXT	Body	Uplevel Radio	V	V																			V																																			
T	2006	TrailBlazer EXT	Body	Navigation Radio	V	V																		V																																				
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto	V	V																		V	V																																			
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual	V	V																		V	V																																			
T	2006	TrailBlazer EXT	Body	Rear Seat Audio	V	V																			V																																			
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint	V	V																			V																																			
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent	V	V																																																					
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V						V			V	V	V			V	V		V								V													V														
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module	V																			V																																				
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V						V			V	V	V			V	V		V								V													V														
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module	V																			V																																						
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control	V	V																		V	V																																					
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control	V	V																		V	V																																					
T	2007	Colorado	Body	Body Control Module	V	V																		V	V																																					
T	2007	Colorado	Body	Digital Radio Receiver	V	V																			V																																					
T	2007	Colorado	Body	Generator Battery Control Module	V	V																		V	V																																					
T	2007	Colorado	Body	Instrument Panel Cluster	V	V																		V	V																																					
T	2007	Colorado	Body	Passenger Presence System	V																																																								
T	2007	Colorado	Body	Base Radio	V	V																			V																																					
T	2007	Colorado	Body	Uplevel Radio	V	V																			V																																					
T	2007	Colorado	Body	Supplemental Inflatable Restraint	V	V																																																							
T	2007	Colorado	Body	Vehicle Comm. Interface Module	V	V																		V	V																																					
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V	V						V			V	V	V			V	V		V							V														V																
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																											
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module	V	V																		V																																					
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module	V	V	V						V			V	V	V			V	V		V							V														V																
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module	V	V																		V										V	V																											
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module	V	V																		V																																					
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V																
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																											
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																		V																																					
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V																
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																											
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module	V	V																		V																																					
T	2007	Trailblazer	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
T	2007	Trailblazer	Body	Body Control Module	V	V																		V	V																																					
T	2007	Trailblazer	Body	Digital Radio Receiver	V	V																			V																																					
T	2007	Trailblazer	Body	Disc Player and Video Display	V																				V																																					
T	2007	Trailblazer	Body	Driver Door Module	V	V																		V	V																																					
T	2007	Trailblazer	Body	Driver Seat Module	V	V																		V	V																																					
T	2007	Trailblazer	Body	Generator Battery Control Module	V	V																		V	V																																					
T	2007	Trailblazer	Body	HVAC Control Module Auto	V	V																		V	V																																					
T	2007	Trailblazer	Body	HVAC Control Module Manual	V	V																		V	V																																					
T	2007	Trailblazer	Body	Instrument Panel Cluster	V	V																		V	V																																					
T	2007	Trailblazer	Body	Lift Gate Module	V	V																		V	V																																					
T	2007	Trailblazer	Body	Passenger Door Module	V	V																		V	V																																					
T	2007	Trailblazer	Body	Passenger Presence System	V																																																								
T	2007	Trailblazer	Body	Uplevel Radio	V	V																			V																																					
T	2007	Trailblazer	Body	Navigation Radio	V	V																		V																																						
T	2007	Trailblazer	Body	Rear Seat Audio	V	V																			V																																					
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint	V	V																			V																																					
T	2007	Trailblazer	Body	Theft Deterrent Module	V	V																																																							
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module	V	V																		V	V																																					
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V																
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																											
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module	V																			V																																					
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V																
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																											
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module	V																			V																																					
T	2008	Colorado	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
T	2008	Colorado	Body	Body Control Module	V	V																		V	V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2008	Colorado	Body	Digital Radio Receiver	V	V																			V																																					
T	2008	Colorado	Body	Generator Battery Control Module	V	V																		V	V																																					
T	2008	Colorado	Body	Instrument Panel Cluster	V	V																		V	V																																					
T	2008	Colorado	Body	Passenger Presence System	V																																																								
T	2008	Colorado	Body	Base Radio	V	V																			V																																					
T	2008	Colorado	Body	Uplevel Radio	V	V																			V																																					
T	2008	Colorado	Body	Supplemental Inflatable Restraint	V	V																																																							
T	2008	Colorado	Body	Theft Deterrent Module	V	V																																																							
T	2008	Colorado	Body	Vehicle Comm. Interface Module	V	V																		V	V																																					
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V																
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																									
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module	V	V																		V																																					
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V																
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																									
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																		V																																					
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V																
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																									
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
T	2008	TrailBlazer	Body	Body Control Module	V	V																		V	V																																					
T	2008	TrailBlazer	Body	Digital Radio Receiver	V	V																			V																																					
T	2008	TrailBlazer	Body	Disc Player and Video Display	V																				V																																					
T	2008	TrailBlazer	Body	Driver Door Module	V	V																		V	V																																					
T	2008	TrailBlazer	Body	Driver Seat Module	V	V																		V	V																																					
T	2008	TrailBlazer	Body	Generator Battery Control Module	V	V																		V	V																																					
T	2008	TrailBlazer	Body	HVAC Control Module Auto	V	V																		V	V																																					
T	2008	TrailBlazer	Body	HVAC Control Module Manual	V	V																		V	V																																					
T	2008	TrailBlazer	Body	Instrument Panel Cluster	V	V																		V	V																																					
T	2008	TrailBlazer	Body	Lift Gate Module	V	V																		V	V																																					
T	2008	TrailBlazer	Body	Passenger Door Module	V	V																		V	V																																					
T	2008	TrailBlazer	Body	Passenger Presence System	V																																																								
T	2008	TrailBlazer	Body	Uplevel Radio	V	V																			V																																					
T	2008	TrailBlazer	Body	Navigation Radio	V	V																		V																																						
T	2008	TrailBlazer	Body	Rear Seat Audio	V	V																			V																																					
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint	V	V																			V																																					
T	2008	TrailBlazer	Body	Theft Deterrent Module	V	V																																																							
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module	V	V																		V	V																																					
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V																
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																									
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																					
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module	V																			V																																						
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V																
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																									
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																					
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module	V																			V																																						
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V																
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module	V	V																		V										V	V																									
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module	V	V																		V	V																																					
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module	V																			V																																						
T	2009	Colorado	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
T	2009	Colorado	Body	Body Control Module	V	V																		V	V																																					
T	2009	Colorado	Body	Digital Radio Receiver	V	V																		V	V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2009	Colorado	Body	Generator Battery Control Module	V	V																		V	V																																				
T	2009	Colorado	Body	Instrument Panel Cluster	V	V																		V	V																																				
T	2009	Colorado	Body	Passenger Presence System	V																																																							
T	2009	Colorado	Body	Base Radio	V	V																			V																																				
T	2009	Colorado	Body	Uplevel Radio	V	V																			V																																				
T	2009	Colorado	Body	Supplemental Inflatable Restraint	V	V																																																						
T	2009	Colorado	Body	Theft Deterrent Module	V	V																																																						
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																									
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module	V	V																		V																																				
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																									
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																		V																																				
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																									
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
T	2009	TrailBlazer	Body	Body Control Module	V	V																		V	V																																			
T	2009	TrailBlazer	Body	Digital Radio Receiver	V	V																		V	V																																			
T	2009	TrailBlazer	Body	Disc Player and Video Display	V																				V																																			
T	2009	TrailBlazer	Body	Driver Door Module	V	V																		V	V																																			
T	2009	TrailBlazer	Body	Driver Seat Module	V	V																		V	V																																			
T	2009	TrailBlazer	Body	Generator Battery Control Module	V	V																		V	V																																			
T	2009	TrailBlazer	Body	HVAC Control Module Auto	V	V																		V	V																																			
T	2009	TrailBlazer	Body	HVAC Control Module Manual	V	V																		V	V																																			
T	2009	TrailBlazer	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2009	TrailBlazer	Body	Lift Gate Module	V	V																		V	V																																			
T	2009	TrailBlazer	Body	Passenger Door Module	V	V																		V	V																																			
T	2009	TrailBlazer	Body	Passenger Presence System	V																																																							
T	2009	TrailBlazer	Body	Uplevel Radio	V	V																			V																																			
T	2009	TrailBlazer	Body	Navigation Radio	V	V																		V																																				
T	2009	TrailBlazer	Body	Rear Seat Audio	V	V																			V																																			
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint	V	V																			V																																			
T	2009	TrailBlazer	Body	Theft Deterrent Module	V	V																																																						
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																			
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module	V																			V																																				
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																			
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module	V																			V																																				
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module	V	V																		V										V	V																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																			
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module	V																			V																																				
T	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
T	2010	ALL	Body	Body Control Module	V	V																		V	V																																			
T	2010	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
T	2010	ALL	Body	Generator Battery Control Module	V	V																		V	V																																			
T	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2010	ALL	Body	Passenger Presence System	V																																																						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2010	ALL	Body	Personal Audio Link Module	V																				V																																					
T	2010	ALL	Body	Base Radio	V	V																			V																																				
T	2010	ALL	Body	Uplevel Radio	V	V																			V																																				
T	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																																																							
T	2010	ALL	Body	Theft Deterrent Module	V	V																																																							
T	2010	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																										
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																				
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module	V																			V																																					
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																										
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																				
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module	V																			V																																					
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module	V	V																		V										V	V																										
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																				
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module	V																			V																																					
T	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
T	2011	ALL	Body	Body Control Module	V	V																		V	V																																				
T	2011	ALL	Body	Digital Radio Receiver	V	V																		V	V																																				
T	2011	ALL	Body	Generator Battery Control Module	V	V																		V	V																																				
T	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																				
T	2011	ALL	Body	Passenger Presence System	V																																																							
T	2011	ALL	Body	Personal Audio Link Module	V																				V																																				
T	2011	ALL	Body	Base Radio	V	V																			V																																				
T	2011	ALL	Body	Uplevel Radio	V	V																			V																																				
T	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
T	2011	ALL	Body	Theft Deterrent Module	V	V																																																						
T	2011	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																				
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module	V																			V																																					
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																				
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module	V																			V																																					
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V															
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module	V	V																		V										V	V																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																				
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module	V																			V																																					
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module	V	V																		V	V																																				
T	2012	Colorado (First Gen)	Body	Body Control Module	V	V																		V	V																																				
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver	V	V																		V	V																																				
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module	V	V																		V	V																																				
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster	V	V																		V	V																																				
T	2012	Colorado (First Gen)	Body	Passenger Presence System	V																																																							
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module	V																				V																																				
T	2012	Colorado (First Gen)	Body	Base Radio	V	V																			V																																				
T	2012	Colorado (First Gen)	Body	Uplevel Radio	V	V																			V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint	V	V																																																						
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module	V	V																																																						
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module	V	V																	V	V																																				
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V	V																													
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission	V																		V	V			V	V	V	V	V																													
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission	V																		V	V						V																														
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission	V																		V	V						V																														
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission	V																		V	V						V																														
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission	V																		V	V						V																														
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module	V	V																	V	V									V	V	V	V									V															
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module	V																		V	V				V	V	V	V	V							V	V	V	V	V	V																
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module	V	V																	V	V									V	V	V	V									V															
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module	V	V																	V	V																																				
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module	V	V																	V	V												V										V														
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																	V	V
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module	V																			V																																				
T	2012	Colorado (Second Gen)	Body	Body Control Module	V	V																	V	V																																				
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V																																				
T	2012	Colorado (Second Gen)	Body	Instrument Cluster	V	V																	V	V																																				
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module	V	V																	V	V																																				
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V	V																													
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission	V																		V	V			V	V	V	V	V																													
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V																
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V																
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission	V																		V	V						V																														
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission	V																		V	V						V																														
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission	V																		V	V						V																														
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission	V																		V	V						V																														
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module	V	V																	V	V									V	V	V	V									V															
T	2012	S10	Powertrain	Transfer Case Control Module	V	V																	V	V																																				
T	2012	S10	Chassis	Electronic Brake Control Module	V	V																	V	V												V										V													
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V			
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module	V																			V																																				
T	2012	S10	Body	Body Control Module	V	V																	V	V																																				
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module		V																		V																																				
T	2012	S10	Body	Instrument Cluster	V	V																	V	V																																				
T	2012	S10	Body	Trailer Interface Control Module	V	V																	V	V																																				
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission	V																		V	V			V	V	V	V	V																													
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission	V																		V	V			V	V	V	V	V																													
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission	V																		V	V						V																														
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission	V																		V	V						V																														
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission	V																		V	V						V																														
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission	V																		V	V						V																														
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module	V	V																	V	V									V	V	V	V									V															
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V							V	V	V	V		V																
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V							V	V	V	V	V	V																
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module	V	V																	V	V									V	V	V	V									V															
T	2013	Colorado	Powertrain	Transfer Case Control Module	V	V																	V	V																																				
T	2013	Colorado	Chassis	Electronic Brake Control Module	V	V																	V	V												V										V													
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V			
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module	V																			V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2013	Colorado	Body	Body Control Module	V	V																		V	V																																			
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
T	2013	Colorado	Body	Instrument Cluster	V	V																		V	V																																			
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																												
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V																												
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V															
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V															
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission	V																			V	V						V																													
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission	V																			V	V						V																													
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission	V																			V	V						V																													
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission	V																			V	V						V																													
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module	V	V																		V	V									V	V	V	V								V															
T	2013	S10	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
T	2013	S10	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V														
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
T	2013	S10	Body	Body Control Module	V	V																		V	V																																			
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
T	2013	S10	Body	Instrument Cluster	V	V																		V	V																																			
T	2013	S10	Body	Trailer Interface Control Module	V	V																		V	V																																			
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission	V																			V	V						V																													
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission	V																			V	V						V																													
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission	V																			V	V						V																													
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission	V																			V	V						V																													
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module	V	V																		V	V									V	V	V	V								V															
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V								V	V	V	V		V															
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V			V	V	V	V									V	V	V	V	V	V															
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V								V															
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V								V	V	V	V		V															
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V								V	V	V	V	V	V															
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module	V	V																		V	V									V	V	V	V								V															
T	2013	Trailblazer	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
T	2013	Trailblazer	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V														
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
T	2013	Trailblazer	Body	Body Control Module	V	V																		V	V																																			
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
T	2013	Trailblazer	Body	Instrument Cluster	V	V																		V	V																																			
T	2013	Trailblazer	Body	Trailer Interface Control Module	V	V																		V	V																																			
T	2013	Trailblazer	Body	Parking Assist Control Module	V																			V	V																																			
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																												
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V																												
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																			V	V																																			
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																			V	V																																			
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																			V	V																																			
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																			V	V																																			
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module	V	V																		V	V									V	V	V	V								V															
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V								V	V	V	V		V															
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V								V	V	V	V		V															
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module	V	V																		V	V									V	V	V	V								V															
T	2014	Colorado	Powertrain	Transfer Case Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2014	Colorado	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V													
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
T	2014	Colorado	Body	Body Control Module	V	V																		V	V																																		
T	2014	Colorado	Body	Body Control Module	V	V																		V	V																																		
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
T	2014	Colorado	Body	Instrument Cluster	V	V																		V	V																																		
T	2014	Colorado	Body	Radio	V	V																		V	V																																		
T	2014	Colorado	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
T	2014	Colorado	Body	Parking Assist Control Module	V																			V	V																																		
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission	V																			V	V			V	V	V	V	V																											
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission	V																			V	V			V	V	V	V	V																											
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																			V	V																																		
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																			V	V																																		
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																			V	V																																		
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																			V	V																																		
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module	V	V																		V	V									V	V	V	V									V													
T	2014	S10	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
T	2014	S10	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V													
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
T	2014	S10	Body	Body Control Module	V	V																		V	V																																		
T	2014	S10	Body	Body Control Module	V	V																		V	V																																		
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
T	2014	S10	Body	Instrument Cluster	V	V																		V	V																																		
T	2014	S10	Body	Trailer Interface Control Module	V	V																		V	V																																		
T	2014	S10	Body	Radio	V	V																		V	V																																		
T	2014	S10	Body	Parking Assist Control Module	V	V																		V	V																																		
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																			V	V																																		
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																			V	V																																		
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																			V	V																																		
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																			V	V																																		
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module	V	V																		V	V									V	V	V	V									V													
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V													
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
T	2014	Trailblazer	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
T	2014	Trailblazer	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V													
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
T	2014	Trailblazer	Body	Body Control Module	V	V																		V	V																																		
T	2014	Trailblazer	Body	Body Control Module	V	V																		V	V																																		
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
T	2014	Trailblazer	Body	Instrument Cluster	V	V																		V	V																																		
T	2014	Trailblazer	Body	Trailer Interface Control Module	V	V																		V	V																																		
T	2014	Trailblazer	Body	Parking Assist Control Module	V																			V	V																																		
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																											
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V											V															
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V									V	V	V	V									V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																		V	V																																				
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																		V	V																																				
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																		V	V																																				
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																		V	V																																				
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module	V	V																	V	V										V	V	V	V									V													
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V							V	V	V	V		V														
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V							V	V	V	V	V	V														
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																	V	V										V	V	V	V								V													
T	2015	Colorado	Powertrain	Chassis Control Module	V	V									V								V	V							V																												
T	2015	Colorado	Powertrain	Transfer Case Control Module	V	V																	V	V																																			
T	2015	Colorado	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V						V
T	2015	Colorado	Chassis	Power Steering Control Module	V	V																		V																																		
T	2015	Colorado	Body	Body Control Module	V	V																	V	V																																		
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
T	2015	Colorado	Body	Passenger Presence Module	V	V																		V																																		
T	2015	Colorado	Body	Radio	V	V																	V	V																																		
T	2015	Colorado	Body	Amplifier	V	V																		V																																		
T	2015	Colorado	Body	Human Machine Interface Control Module	V	V																	V	V																							V											
T	2015	Colorado	Body	Telematics Communication Interface Control Module	V	V																	V	V																																		
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)	V	V																	V	V																																		
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)	V	V																	V	V																																		
T	2015	Colorado	Body	Frontview Camera Module	V	V																	V	V																																		
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																		V	V	V	V	V	V	V	V	V	V																										
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																		V	V	V	V	V	V	V	V	V	V												V														
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																	V	V										V	V	V	V									V													
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																		V	V																																			
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																		V	V																																			
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																		V	V																																			
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																		V	V																																			
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module	V	V																	V	V										V	V	V	V									V													
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V							V	V	V	V		V														
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V							V	V	V	V	V	V														
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																	V	V										V	V	V	V									V													
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module	V	V																	V	V																																			
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V											
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																		V	V
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module	V																			V																																			
T	2015	Colorado (MMM)	Body	Body Control Module	V	V																	V	V																																		
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																		
T	2015	Colorado (MMM)	Body	Instrument Cluster	V	V																	V	V																																		
T	2015	Colorado (MMM)	Body	Radio	V	V																	V	V																																		
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module	V	V																	V	V																																		
T	2015	Colorado (MMM)	Body	Parking Assist Control Module	V	V																		V																																		
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V													
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V													
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																		V	V	V	V	V	V	V	V	V	V																										
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																		V	V	V	V	V	V	V	V	V	V												V														
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																	V	V										V	V	V	V									V													
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																		V	V																																			
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																		V	V																																			
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																		V	V																																			
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module	V	V																	V	V									V	V	V	V									V													
T	2015	S10	Powertrain	Transfer Case Control Module	V	V																	V	V																																		
T	2015	S10	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V											
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
T	2015	S10	Body	Body Control Module	V	V																	V	V																																	
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																	
T	2015	S10	Body	Instrument Cluster	V	V																	V	V																																	
T	2015	S10	Body	Trailer Interface Control Module	V	V																	V	V																																	
T	2015	S10	Body	Radio	V	V																	V	V																																	
T	2015	S10	Body	Telematics Communication Interface Control Module	V	V																	V	V																																	
T	2015	S10	Body	Parking Assist Control Module	V	V																		V																																	
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																		V	V																																	
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																		V	V																																	
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission	V																		V	V																																	
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission	V																		V	V																																	
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module	V	V																	V	V									V	V	V	V									V													
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V	V							V	V	V	V		V													
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																		V	V				V	V	V	V	V							V	V	V	V	V	V													
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																	V	V									V	V	V	V									V													
T	2015	Trailblazer	Powertrain	Transfer Case Control Module	V	V																	V	V																																	
T	2015	Trailblazer	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V											
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																																V	V
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module	V																			V																																	
T	2015	Trailblazer	Body	Body Control Module	V	V																	V	V																																	
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																	
T	2015	Trailblazer	Body	Instrument Cluster	V	V																	V	V																																	
T	2015	Trailblazer	Body	Trailer Interface Control Module	V	V																	V	V																																	
T	2015	Trailblazer	Body	Radio	V	V																	V	V																																	
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module	V	V																	V	V																																	
T	2015	Trailblazer	Body	Parking Assist Control Module	V	V																		V																																	
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																		V	V	V	V	V	V	V	V	V																									
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																		V	V	V	V	V	V	V	V	V												V													
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																	V	V									V	V	V	V									V													
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module	V																		V	V																																	
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module	V	V																	V	V									V	V	V	V									V													
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module	V																		V	V				V	V	V	V	V							V	V	V	V	V	V													
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																	V	V									V	V	V	V									V													
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module	V	V																	V	V																																	
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V					V
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module	V	V																		V																																	
T	2016	Colorado (1GC)	Body	Body Control Module	V	V																	V	V																																	
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																	
T	2016	Colorado (1GC)	Body	Passenger Presence Module	V	V																		V																																	
T	2016	Colorado (1GC)	Body	Radio Controls	V																			V																																	
T	2016	Colorado (1GC)	Body	HVAC Controls	V																		V	V																																	
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module	V	V																	V	V																																	
T	2016	Colorado (1GC)	Body	Radio	V	V																	V	V																																	
T	2016	Colorado (1GC)	Body	Amplifier	V	V																		V																																	
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module	V	V																	V	V																						V												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
T	2016	Colorado (1GC)	Body	Frontview Camera Module	V	V																		V	V																																			
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																												
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V	V											V																
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																			V	V						V																												
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																			V	V						V																												
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission	V																			V	V						V																												
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission	V																			V	V						V																												
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module	V	V																		V	V									V	V	V	V									V												
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V												
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V											V	
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
T	2016	Colorado (MMM)	Body	Body Control Module	V	V																		V	V																																			
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
T	2016	Colorado (MMM)	Body	Instrument Cluster	V	V																		V	V																																			
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module	V	V																		V	V																																			
T	2016	Colorado (MMM)	Body	Radio	V	V																		V	V																																			
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
T	2016	Colorado (MMM)	Body	Parking Assist Control Module	V																			V	V																																			
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module	V																			V	V				V	V	V	V													V														
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V	V																												
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V	V											V																
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V									V	V	V	V									V														
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission	V																			V	V						V																												
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission	V																			V	V						V																												
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module	V	V																		V	V									V	V	V	V									V														
T	2016	S10	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
T	2016	S10	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V											V	
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
T	2016	S10	Body	Body Control Module	V	V																		V	V																																			
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
T	2016	S10	Body	Instrument Cluster	V	V																		V	V																																			
T	2016	S10	Body	Trailer Interface Control Module	V	V																		V	V																																			
T	2016	S10	Body	Radio	V	V																		V	V																																			
T	2016	S10	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
T	2016	S10	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
T	2016	S10	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
T	2016	S10	Body	Parking Assist Control Module	V																			V	V																																			
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission	V																			V	V						V																												
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission	V																			V	V						V																												
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission	V																			V	V						V																												
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission	V																			V	V						V																												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module	V	V																		V	V										V	V	V	V									V													
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V	V	V													
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V													
T	2016	Trailblazer	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
T	2016	Trailblazer	Chassis	Electronic Brake Control Module	V	V																		V	V													V											V										V	
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
T	2016	Trailblazer	Body	Body Control Module	V	V																		V	V																																			
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
T	2016	Trailblazer	Body	Instrument Cluster	V	V																		V	V																																			
T	2016	Trailblazer	Body	Trailer Interface Control Module	V	V																		V	V																																			
T	2016	Trailblazer	Body	Radio	V	V																		V	V																																			
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
T	2016	Trailblazer	Body	Parking Assist Control Module	V																			V	V																																			
V	2009	ALL	Powertrain	Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V															V	V	V	V																
V	2009	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
V	2009	ALL	Powertrain	Rear Drive System	V	V																			V																																			
V	2009	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
V	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
V	2009	ALL	Body	Body Control Module	V	V																		V	V																																			
V	2009	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
V	2009	ALL	Body	Driver Door Switch	V	V																		V	V																																			
V	2009	ALL	Body	Heated Seat Module	V	V																			V																																			
V	2009	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
V	2009	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
V	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
V	2009	ALL	Body	Lift Gate Module	V	V																		V	V																																			
V	2009	ALL	Body	Park Assist Module	V	V																		V	V																																			
V	2009	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
V	2009	ALL	Body	Passenger Presence System	V	V																			V																																			
V	2009	ALL	Body	Radio	V	V																		V	V																																			
V	2009	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
V	2009	ALL	Body	Rollover Sensor	V	V																			V																																			
V	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
V	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																			
V	2010	ALL	Powertrain	Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V							V									V	V	V	V																
V	2010	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
V	2010	ALL	Powertrain	Rear Drive System	V	V																			V																																			
V	2010	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
V	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
V	2010	ALL	Body	Body Control Module	V	V																		V	V																																			
V	2010	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
V	2010	ALL	Body	Driver Door Switch	V	V																		V	V																																			
V	2010	ALL	Body	Heated Seat Module	V	V																			V																																			
V	2010	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
V	2010	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
V	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
V	2010	ALL	Body	Lift Gate Module	V	V																		V	V																																			
V	2010	ALL	Body	Park Assist Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
V	2010	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
V	2010	ALL	Body	Passenger Presence System	V	V																			V																																			
V	2010	ALL	Body	Radio	V	V																		V	V																																			
V	2010	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
V	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
V	2010	ALL	Body	Theft Deterrent Module	V	V																			V																																			
V	2011	ALL	Powertrain	Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V																
V	2011	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
V	2011	ALL	Powertrain	Rear Drive System	V	V																			V																																			
V	2011	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V	V																								
V	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
V	2011	ALL	Body	Body Control Module	V	V																		V	V																																			
V	2011	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
V	2011	ALL	Body	Driver Door Switch	V	V																		V	V																																			
V	2011	ALL	Body	Heated Seat Module	V	V																			V																																			
V	2011	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
V	2011	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
V	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
V	2011	ALL	Body	Lift Gate Module	V	V																		V	V																																			
V	2011	ALL	Body	Park Assist Module	V	V																			V																																			
V	2011	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
V	2011	ALL	Body	Passenger Presence System	V	V																			V																																			
V	2011	ALL	Body	Radio	V	V																		V	V																																			
V	2011	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
V	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
V	2011	ALL	Body	Theft Deterrent Module	V	V																			V																																			
V	2012	ALL	Powertrain	Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V														
V	2012	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
V	2012	ALL	Powertrain	Rear Drive System	V	V																			V																																			
V	2012	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V	V																								
V	2012	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		V	
V	2012	ALL	Body	Body Control Module	V	V																		V	V																																			
V	2012	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
V	2012	ALL	Body	Driver Door Switch	V	V																		V	V																																			
V	2012	ALL	Body	Heated Seat Module	V	V																			V																																			
V	2012	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
V	2012	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
V	2012	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
V	2012	ALL	Body	Lift Gate Module	V	V																		V	V																																			
V	2012	ALL	Body	Park Assist Module	V	V																			V																																			
V	2012	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
V	2012	ALL	Body	Passenger Presence System	V	V																			V																																			
V	2012	ALL	Body	Radio	V	V																		V	V																																			
V	2012	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
V	2012	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
V	2012	ALL	Body	Theft Deterrent Module	V	V																			V																																			
V	2013	ALL	Powertrain	Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V														
V	2013	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
V	2013	ALL	Powertrain	Rear Drive System	V	V																			V																																			
V	2013	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V	V																								
V	2013	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		V	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
V	2013	ALL	Body	Body Control Module	V	V																		V	V																																			
V	2013	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
V	2013	ALL	Body	Driver Door Switch	V	V																		V	V																																			
V	2013	ALL	Body	Heated Seat Module	V	V																			V																																			
V	2013	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
V	2013	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
V	2013	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
V	2013	ALL	Body	Left Side Object Detection Module	V																			V	V																																			
V	2013	ALL	Body	Lift Gate Module	V	V																		V	V																																			
V	2013	ALL	Body	Park Assist Module	V	V																			V																																			
V	2013	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
V	2013	ALL	Body	Passenger Presence System	V	V																			V																																			
V	2013	ALL	Body	Radio	V	V																		V	V																																			
V	2013	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
V	2013	ALL	Body	Right Side Object Detection Module	V																			V	V																																			
V	2013	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																			
V	2013	ALL	Body	Theft Deterrent Module	V	V																			V																																			
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V														
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V									V												
V	2014	Traverse	Powertrain	Chassis Control Module	V	V																		V	V							V		V																									
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																			
V	2014	Traverse	Chassis	Electronic Brake Control Module	V	V																		V	V												V												V	V	V	V	V	V					V
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																			
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																			
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
V	2014	Traverse	Body	Passenger Presence Module	V	V																			V																																			
V	2014	Traverse	Body	Instrument Cluster	V	V																		V	V																																			
V	2014	Traverse	Body	Radio	V	V																		V	V																																			
V	2014	Traverse	Body	Rear Audio Control Module	V	V																			V																																			
V	2014	Traverse	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
V	2014	Traverse	Body	Personal Audio Link Control Module	V																				V																																			
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
V	2014	Traverse	Body	Driver Door Switch Panel Control Module	V	V																		V	V																							V											
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																			
V	2014	Traverse	Body	Liftgate Control Module	V	V																			V																							V											
V	2014	Traverse	Body	Seat Memory Control Module	V	V																		V	V																																			
V	2014	Traverse	Body	Front Seat Heating Control Module	V	V																			V																																			
V	2014	Traverse	Body	Right Side Object Detection Control Module	V																			V	V																																			
V	2014	Traverse	Body	Left Side Object Detection Control Module	V																			V	V																																			
V	2014	Traverse	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
V	2014	Traverse	Body	Parking Assist Control Module	V																			V	V																																			
V	2014	Traverse	Body	Frontview Camera Module	V	V																		V	V																																			
V	2014	Traverse	Body	Theft Deterrent Module	V	V																			V																																			
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V														
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V									V												
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																			
V	2015	Traverse	Chassis	Electronic Brake Control Module	V	V																		V	V												V												V	V	V	V	V	V					V
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																				
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
V	2015	Traverse	Body	Passenger Presence Module	V	V																			V																																			
V	2015	Traverse	Body	Instrument Cluster	V	V																		V	V																																			
V	2015	Traverse	Body	Radio	V	V																		V	V																																			
V	2015	Traverse	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
V	2015	Traverse	Body	Liftgate Control Module	V	V																			V																						V													
V	2015	Traverse	Body	Seat Memory Control Module	V	V																		V	V																																			
V	2015	Traverse	Body	Front Seat Heating Control Module	V	V																			V																																			
V	2015	Traverse	Body	Right Side Object Detection Control Module	V																			V	V																																			
V	2015	Traverse	Body	Left Side Object Detection Control Module	V																			V	V																																			
V	2015	Traverse	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
V	2015	Traverse	Body	Parking Assist Control Module	V																			V	V																																			
V	2015	Traverse	Body	Frontview Camera Module	V	V																		V	V																																			
V	2015	Traverse	Body	Theft Deterrent Module	V	V																			V																																			
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V		V															
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V									V	V	V	V								V														
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																			
V	2016	Traverse	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V					V
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																			
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																			
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
V	2016	Traverse	Body	Passenger Presence Module	V	V																			V																																			
V	2016	Traverse	Body	Instrument Cluster	V	V																		V	V																																			
V	2016	Traverse	Body	Radio	V	V																		V	V																																			
V	2016	Traverse	Body	Rear Audio Control Module	V	V																			V																																			
V	2016	Traverse	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
V	2016	Traverse	Body	Personal Audio Link Control Module	V																				V																																			
V	2016	Traverse	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
V	2016	Traverse	Body	Driver Door Switch Panel Control Module	V	V																		V	V																					V														
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																			
V	2016	Traverse	Body	Liftgate Control Module	V	V																			V																					V														
V	2016	Traverse	Body	Seat Memory Control Module	V	V																		V	V																																			
V	2016	Traverse	Body	Front Seat Heating Control Module	V	V																			V																																			
V	2016	Traverse	Body	Right Side Object Detection Control Module	V																			V	V																																			
V	2016	Traverse	Body	Left Side Object Detection Control Module	V																			V	V																																			
V	2016	Traverse	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
V	2016	Traverse	Body	Parking Assist Control Module	V																			V	V																																			
V	2016	Traverse	Body	Frontview Camera Module	V	V																		V	V																																			
V	2016	Traverse	Body	Theft Deterrent Module	V	V																			V																																			
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																												
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V												V																
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																													
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V																

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
A	2011	Orlando	Powertrain	Fuel Injector Control Module	V	V									V					V				V	V																																		
A	2011	Orlando	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V						
A	2011	Orlando	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
A	2011	Orlando	Chassis	Power Steering Control Module	V	V																			V																																	
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
A	2011	Orlando	Body	Body Control Module	V	V																		V	V																																	
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
A	2011	Orlando	Body	Instrument Cluster	V	V																		V	V																																	
A	2011	Orlando	Body	Trailer Interface Control Module	V	V																		V	V																																	
A	2011	Orlando	Body	Radio	V	V																		V	V																																	
A	2011	Orlando	Body	Multimedia Player Interface Module	V	V																			V																																	
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)	V	V																		V	V																																	
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)	V	V																		V	V																																	
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)	V	V																		V	V																																	
A	2011	Orlando	Body	Keyless Entry Control Module	V	V																		V	V																																	
A	2011	Orlando	Body	Parking Assist Control Module	V	V																		V	V																																	
A	2011	Orlando	Body	Steering Column Lock Control Module	V	V																			V																																	
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																											
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V												V															
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																											
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V														
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V												V													
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V	V											V														
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																			
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module	V	V																		V	V							V		V																								
A	2012	Orlando	Powertrain	Fuel Injector Control Module	V	V									V					V				V	V																																	
A	2012	Orlando	Chassis	Electronic Brake Control Module	V	V																		V	V													V									V	V	V	V	V	V						
A	2012	Orlando	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
A	2012	Orlando	Chassis	Power Steering Control Module	V	V																			V																																	
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
A	2012	Orlando	Body	Body Control Module	V	V																		V	V																																	
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
A	2012	Orlando	Body	Instrument Cluster	V	V																		V	V																																	
A	2012	Orlando	Body	Trailer Interface Control Module	V	V																		V	V																																	
A	2012	Orlando	Body	Radio	V	V																		V	V																																	
A	2012	Orlando	Body	Multimedia Player Interface Module	V	V																			V																																	
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)	V	V																		V	V																																	
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)	V	V																		V	V																																	
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)	V	V																		V	V																																	
A	2012	Orlando	Body	Keyless Entry Control Module	V	V																		V	V																																	
A	2012	Orlando	Body	Parking Assist Control Module	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2012	Orlando	Body	Steering Column Lock Control Module	V	V																			V																																			
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V																										
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V												V														
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V						V	V																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V						V	V												V														
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission	V																			V	V				V	V	V	V												V	V														
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module	V	V									V					V				V	V																																		
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																												
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V														
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V											V	V														
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission	V																			V	V	V	V		V	V	V	V	V											V	V														
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module	V	V																		V	V							V		V																									
A	2013	Orlando	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
A	2013	Orlando	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
A	2013	Orlando	Chassis	Power Steering Control Module	V	V																			V																																	
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
A	2013	Orlando	Body	Body Control Module	V	V																		V	V																																	
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
A	2013	Orlando	Body	Instrument Cluster	V	V																		V	V																																	
A	2013	Orlando	Body	Radio	V	V																		V	V																																	
A	2013	Orlando	Body	Digital Radio Receiver Control Module	V	V																			V																																	
A	2013	Orlando	Body	Multimedia Player Interface Module	V	V																			V																																	
A	2013	Orlando	Body	Mobile Telephone Control Module	V	V																		V	V																																	
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																	
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																	
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																	
A	2013	Orlando	Body	Front Seat Heating Control Module	V	V																		V	V																																	
A	2013	Orlando	Body	Keyless Entry Control Module	V	V																		V	V																																	
A	2013	Orlando	Body	Parking Assist Control Module	V	V																		V	V																																	
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V																										
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V												V														
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V																										
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V												V														
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V						V	V																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V						V	V												V														
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V													V														
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V														
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V													V														
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V												V													
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V													
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2014	Orlando	Powertrain	Fuel Injector Control Module		V																		V	V																																	
A	2014	Orlando	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
A	2014	Orlando	Chassis	Power Steering Control Module	V	V																			V																																	
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
A	2014	Orlando	Body	Body Control Module	V	V																		V	V																																	
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
A	2014	Orlando	Body	Instrument Cluster	V	V																		V	V																																	
A	2014	Orlando	Body	Radio	V	V																		V	V																																	
A	2014	Orlando	Body	Digital Radio Receiver Control Module	V	V																			V																																	
A	2014	Orlando	Body	Multimedia Player Interface Module	V	V																			V																																	
A	2014	Orlando	Body	Mobile Telephone Control Module	V	V																		V	V																																	
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																	
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																	
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																	
A	2014	Orlando	Body	Front Seat Heating Control Module	V	V																		V	V																																	
A	2014	Orlando	Body	Rear Seat Heating Control Module	V	V																		V	V																																	
A	2014	Orlando	Body	Keyless Entry Control Module	V	V																		V	V																																	
A	2014	Orlando	Body	Parking Assist Control Module	V	V																		V	V																																	
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																										
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V													
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V													
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V																											
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V														V													
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V												V													
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V													
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2015	Orlando	Powertrain	Fuel Injector Control Module	V																																																			
A	2015	Orlando	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V						
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
A	2015	Orlando	Chassis	Power Steering Control Module	V	V																			V																																	
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
A	2015	Orlando	Body	Body Control Module	V	V																		V	V																																	
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
A	2015	Orlando	Body	Instrument Cluster	V	V																		V	V																																	
A	2015	Orlando	Body	Radio	V	V																		V	V																																	
A	2015	Orlando	Body	Digital Radio Receiver Control Module	V	V																			V																																	
A	2015	Orlando	Body	Mobile Telephone Control Module	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
A	2015	Orlando	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																		
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
A	2015	Orlando	Body	Front Seat Heating Control Module	V	V																		V	V																																		
A	2015	Orlando	Body	Rear Seat Heating Control Module	V	V																		V	V																																		
A	2015	Orlando	Body	Keyless Entry Control Module	V	V																		V	V																																		
A	2015	Orlando	Body	Parking Assist Control Module	V	V																		V	V																																		
A	2015	Orlando	Body	Frontview Camera Module	V	V																		V	V																																		
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V														
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission	V																			V	V																																		
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission	V																			V	V																																		
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																											
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V												V															
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module	V																			V	V				V	V	V	V														V													
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																											
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V													V														
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V												V													
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission	V																			V	V	V	V		V	V	V	V												V	V													
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
A	2016	Orlando	Powertrain	Fuel Injector Control Module	V																																																					
A	2016	Orlando	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V							
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
A	2016	Orlando	Chassis	Power Steering Control Module	V	V																			V																																		
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
A	2016	Orlando	Body	Body Control Module	V	V																		V	V																																		
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
A	2016	Orlando	Body	Instrument Cluster	V	V																		V	V																																		
A	2016	Orlando	Body	Radio	V	V																		V	V																																		
A	2016	Orlando	Body	Digital Radio Receiver Control Module	V	V																			V																																		
A	2016	Orlando	Body	Multimedia Player Interface Module	V	V																			V																																		
A	2016	Orlando	Body	Mobile Telephone Control Module	V	V																		V	V																																		
A	2016	Orlando	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																		
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
A	2016	Orlando	Body	Front Seat Heating Control Module	V	V																		V	V																																		
A	2016	Orlando	Body	Rear Seat Heating Control Module	V	V																		V	V																																		
A	2016	Orlando	Body	Keyless Entry Control Module	V	V																		V	V																																		
A	2016	Orlando	Body	Parking Assist Control Module	V																			V	V																																		
A	2016	Orlando	Body	Frontview Camera Module	V	V																		V	V																																		
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module	V	V	V			V					V			V	V			V		V	V																																		
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module	V	V	V			V					V			V	V			V		V	V																																		
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module	V	V	V			V					V			V	V			V		V	V																																		
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module	V	V	V			V					V			V	V			V		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module	V	V	V			V					V			V	V			V		V	V																																				
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module	V	V	V			V					V			V	V			V		V	V																																			
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module	V	V											V							V	V																																			
C	2009	N200	Chassis	Electronic Brake Control Module	V	V																		V																																				
C	2009	N200	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module	V	V											V							V	V																																			
C	2009	N300	Chassis	Electronic Brake Control Module	V	V																		V																																				
C	2009	N300	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module	V	V											V							V	V																																			
C	2010	N200	Chassis	Electronic Brake Control Module	V	V																		V																																				
C	2010	N200	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module	V	V											V							V	V																																			
C	2010	N300	Chassis	Electronic Brake Control Module	V	V																		V																																				
C	2010	N300	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module	V	V											V							V	V																																			
C	2011	N200	Chassis	Electronic Brake Control Module	V	V																		V																																				
C	2011	N200	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module	V	V											V							V	V																																			
C	2011	N300	Chassis	Electronic Brake Control Module	V	V																		V																																				
C	2011	N300	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module	V	V											V							V	V																																			
C	2012	N200	Chassis	Electronic Brake Control Module	V	V																		V																																				
C	2012	N200	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module	V	V											V							V	V																																			
C	2012	N300	Chassis	Electronic Brake Control Module	V	V																		V																																				
C	2012	N300	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
C	2013	N300	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
C	2014	N300	Powertrain	1.5L L3C Engine Control Module	V	V	V		V	V			V				V					V		V																																			
C	2014	N300	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module	V	V	V		V	V			V				V					V		V																																			
C	2015	Max	Powertrain	1.5L L3C Engine Control Module	V	V	V		V	V			V				V					V		V																																			
C	2015	Max	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module	V	V	V		V	V			V				V					V		V																																			
C	2015	Move	Powertrain	1.5L L3C Engine Control Module	V	V	V		V	V			V				V					V		V																																			
C	2015	Move	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module	V	V	V		V	V			V				V					V		V																																			
C	2015	N300	Powertrain	1.5L L3C Engine Control Module	V	V	V		V	V			V				V					V		V																																			
C	2015	N300	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																				
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module	V	V	V			V			V			V	V					V		V	V																																			
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module	V	V	V		V	V			V				V					V		V																																				
C	2016	Max	Powertrain	1.5L L3C Engine Control Module	V	V	V		V	V			V				V					V		V																																				
C	2016	Max	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module	V	V	V			V			V			V	V					V		V	V																																		
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module	V	V	V		V	V			V				V					V		V																																			
C	2016	Move	Powertrain	1.5L L3C Engine Control Module	V	V	V		V	V			V				V					V		V																																			
C	2016	Move	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module	V	V	V			V			V			V	V					V		V	V																																		
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module	V	V	V		V	V			V				V					V		V																																			
C	2016	N300	Powertrain	1.5L L3C Engine Control Module	V	V	V		V	V			V				V					V		V																																			
C	2016	N300	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module	V																				V																																		
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module	V	V																			V																																		
M	2015	City Express	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V											
M	2015	City Express	Chassis	Power Steering Control Module	V	V																			V																																		
M	2015	City Express	Body	Body Control Module	V	V																		V	V																																		
M	2015	City Express	Body	Underhood Fuse Block	V	V																		V	V																																		
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
M	2015	City Express	Body	Instrument Cluster	V	V																																																				
M	2015	City Express	Body	Tire Pressure Indicator Module	V	V																		V	V																																		
M	2015	City Express	Body	Radio	V	V																			V																																		
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module	V																				V																																		
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module	V	V																			V																																		
M	2016	City Express	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V											
M	2016	City Express	Chassis	Power Steering Control Module	V	V																			V																																		
M	2016	City Express	Body	Body Control Module	V	V																		V	V																																		
M	2016	City Express	Body	Underhood Fuse Block	V	V																		V	V																																		
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
M	2016	City Express	Body	Instrument Cluster	V	V																																																				
M	2016	City Express	Body	Tire Pressure Indicator Module	V	V																		V	V																																		
M	2016	City Express	Body	Radio	V	V																			V																																		
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																												
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V												V																
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																												
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V															
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2011	Orlando	Powertrain	Fuel Injector Control Module	V	V									V					V				V	V																																		
P	2011	Orlando	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V							
P	2011	Orlando	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V			
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
P	2011	Orlando	Chassis	Power Steering Control Module	V	V																			V																																		
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2011	Orlando	Body	Body Control Module	V	V																		V	V																																			
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
P	2011	Orlando	Body	Instrument Cluster	V	V																		V	V																																			
P	2011	Orlando	Body	Trailer Interface Control Module	V	V																		V	V																																			
P	2011	Orlando	Body	Radio	V	V																		V	V																																			
P	2011	Orlando	Body	Multimedia Player Interface Module		V																			V																																			
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)	V	V																		V	V																																			
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)	V	V																		V	V																																			
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)	V	V																		V	V																																			
P	2011	Orlando	Body	Keyless Entry Control Module	V	V																		V	V																																			
P	2011	Orlando	Body	Parking Assist Control Module	V	V																		V	V																																			
P	2011	Orlando	Body	Steering Column Lock Control Module	V	V																			V																																			
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																												
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V														
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission	V																			V	V				V	V	V	V													V	V													
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																												
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V															
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V													V													
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V	V												V														
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module	V	V																		V	V							V		V																								
P	2012	Orlando	Powertrain	Fuel Injector Control Module	V	V									V					V				V	V																																		
P	2012	Orlando	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V							
P	2012	Orlando	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V			
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
P	2012	Orlando	Chassis	Power Steering Control Module	V	V																			V																																		
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
P	2012	Orlando	Body	Body Control Module	V	V																		V	V																																		
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
P	2012	Orlando	Body	Instrument Cluster	V	V																		V	V																																		
P	2012	Orlando	Body	Trailer Interface Control Module	V	V																		V	V																																		
P	2012	Orlando	Body	Radio	V	V																		V	V																																		
P	2012	Orlando	Body	Multimedia Player Interface Module	V	V																			V																																		
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)	V	V																		V	V																																		
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)	V	V																		V	V																																		
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)	V	V																		V	V																																		
P	2012	Orlando	Body	Keyless Entry Control Module	V	V																		V	V																																		
P	2012	Orlando	Body	Parking Assist Control Module	V	V																		V	V																																		
P	2012	Orlando	Body	Steering Column Lock Control Module	V	V																			V																																		
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V												V														
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V													
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V														
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V	V													
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module	V	V									V					V			V	V																																	
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																		V	V			V			V																											
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V			V	V			V			V													V													
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission	V																		V	V	V	V		V	V	V	V	V											V	V													
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission	V																		V	V	V	V		V	V	V	V	V											V	V													
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module	V	V																	V	V							V		V																								
P	2013	Orlando	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V					
P	2013	Orlando	Chassis	Parking Brake Control Module	V	V																		V																					V							V	V	V	V		
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																															V	V
P	2013	Orlando	Chassis	Power Steering Control Module	V	V																		V																																
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module	V																			V																																
P	2013	Orlando	Body	Body Control Module	V	V																	V	V																																
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																	V	V																																
P	2013	Orlando	Body	Instrument Cluster	V	V																	V	V																																
P	2013	Orlando	Body	Radio	V	V																	V	V																																
P	2013	Orlando	Body	Digital Radio Receiver Control Module	V	V																		V																																
P	2013	Orlando	Body	Multimedia Player Interface Module	V	V																		V																																
P	2013	Orlando	Body	Mobile Telephone Control Module	V	V																	V	V																																
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9	V	V																	V	V																																
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10	V	V																	V	V																																
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)	V	V																	V	V																																
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)	V	V																	V	V																																
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)	V	V																	V	V																																
P	2013	Orlando	Body	Front Seat Heating Control Module	V	V																	V	V																																
P	2013	Orlando	Body	Keyless Entry Control Module	V	V																	V	V																																
P	2013	Orlando	Body	Parking Assist Control Module	V	V																	V	V																																
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V																									
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V												V													
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V																									
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V					V		V												V													
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V						V	V																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V	V						V	V												V													
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission	V																		V	V				V	V	V	V													V													
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission	V																		V	V				V	V	V	V													V													
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V			V	V			V			V																											
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V			V	V			V			V													V													
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission	V																		V	V	V	V		V	V	V	V	V											V														
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission	V																		V	V	V	V	V	V	V	V	V												V													
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																	V	V										V	V	V	V	V	V																		
P	2014	Orlando	Powertrain	Fuel Injector Control Module		V																	V	V																																
P	2014	Orlando	Chassis	Electronic Brake Control Module	V	V																	V	V													V										V	V	V	V	V	V					
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module	V																			V																															V	V

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2014	Orlando	Chassis	Power Steering Control Module	V	V																			V																																			
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
P	2014	Orlando	Body	Body Control Module	V	V																		V	V																																			
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
P	2014	Orlando	Body	Instrument Cluster	V	V																		V	V																																			
P	2014	Orlando	Body	Radio	V	V																		V	V																																			
P	2014	Orlando	Body	Digital Radio Receiver Control Module	V	V																			V																																			
P	2014	Orlando	Body	Multimedia Player Interface Module	V	V																			V																																			
P	2014	Orlando	Body	Mobile Telephone Control Module	V	V																		V	V																																			
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																			
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
P	2014	Orlando	Body	Front Seat Heating Control Module	V	V																		V	V																																			
P	2014	Orlando	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
P	2014	Orlando	Body	Keyless Entry Control Module	V	V																		V	V																																			
P	2014	Orlando	Body	Parking Assist Control Module	V	V																		V	V																																			
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																												
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V														
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																											
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V														
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V														V													
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission	V																			V	V				V	V	V	V														V													
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V	V	V	V		V	V	V		V	V		V		V	V				V	V			V			V																												
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V	V	V			V	V	V		V	V		V		V	V				V	V			V			V													V														
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V													V													
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V													V														
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V										V	V	V	V	V	V																				
P	2015	Orlando	Powertrain	Fuel Injector Control Module	V																																																					
P	2015	Orlando	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		V	V
P	2015	Orlando	Chassis	Power Steering Control Module	V	V																			V																																			
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
P	2015	Orlando	Body	Body Control Module	V	V																		V	V																																			
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
P	2015	Orlando	Body	Instrument Cluster	V	V																		V	V																																			
P	2015	Orlando	Body	Radio	V	V																		V	V																																			
P	2015	Orlando	Body	Digital Radio Receiver Control Module	V	V																			V																																			
P	2015	Orlando	Body	Mobile Telephone Control Module	V	V																		V	V																																			
P	2015	Orlando	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																			
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
P	2015	Orlando	Body	Front Seat Heating Control Module	V	V																		V	V																																			
P	2015	Orlando	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
P	2015	Orlando	Body	Keyless Entry Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
P	2015	Orlando	Body	Parking Assist Control Module	V	V																		V	V																																			
P	2015	Orlando	Body	Frontview Camera Module	V	V																		V	V																																			
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V																												
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V					V		V													V															
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission	V																			V	V																																			
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission	V																			V	V																																			
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V																												
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission	V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V		V	V						V	V													V															
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module	V																			V	V				V	V	V	V														V														
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission	V																			V	V			V			V																												
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission	V																			V	V			V			V													V															
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission	V																			V	V	V	V		V	V	V	V	V												V														
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission	V																			V	V	V	V		V	V	V	V												V	V														
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																				
P	2016	Orlando	Powertrain	Fuel Injector Control Module	V																																																					
P	2016	Orlando	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V								
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
P	2016	Orlando	Chassis	Power Steering Control Module	V	V																			V																																		
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
P	2016	Orlando	Body	Body Control Module	V	V																		V	V																																		
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
P	2016	Orlando	Body	Instrument Cluster	V	V																		V	V																																		
P	2016	Orlando	Body	Radio	V	V																		V	V																																		
P	2016	Orlando	Body	Digital Radio Receiver Control Module	V	V																			V																																		
P	2016	Orlando	Body	Multimedia Player Interface Module	V	V																			V																																		
P	2016	Orlando	Body	Mobile Telephone Control Module	V	V																		V	V																																		
P	2016	Orlando	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)	V	V																		V	V																																		
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
P	2016	Orlando	Body	Front Seat Heating Control Module	V	V																		V	V																																		
P	2016	Orlando	Body	Rear Seat Heating Control Module	V	V																		V	V																																		
P	2016	Orlando	Body	Keyless Entry Control Module	V	V																		V	V																																		
P	2016	Orlando	Body	Parking Assist Control Module	V																			V	V																																		
P	2016	Orlando	Body	Frontview Camera Module	V	V																		V	V																																		
U	2004	ALL	Powertrain	Engine Control Module	V	V							V			V					V			V	V						V																												
U	2004	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V																							
U	2004	ALL	Body	Digital Radio Receiver	V	V																			V																																		
U	2004	ALL	Body	Driver Information Center	V																																																				
U	2004	ALL	Body	Instrument Panel Cluster	V	V																		V																																		
U	2004	ALL	Body	Radio	V	V																		V																																		
U	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																			
U	2004	ALL	Body	Vehicle Theft Deterrent	V	V																																																			
U	2005	ALL	Powertrain	Engine Control Module	V	V	V						V			V	V	V			V	V		V	V						V																												
U	2005	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V																							
U	2005	ALL	Chassis	Electronic Brake Control Module	V	V																		V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
U	2005	ALL	Body	Body Control Module	V	V																		V	V																																				
U	2005	ALL	Body	Disc Player and Video	V																				V																																				
U	2005	ALL	Body	Digital Radio Receiver	V	V																			V																																				
U	2005	ALL	Body	HVAC Control Module	V	V																		V																																				
U	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
U	2005	ALL	Body	Left Power Sliding Door Module	V	V																		V	V																																			
U	2005	ALL	Body	Mobile Digital Media	V																																																							
U	2005	ALL	Body	Navigation Radio	V	V																		V	V																																			
U	2005	ALL	Body	Navigation Radio	V	V																		V																																				
U	2005	ALL	Body	Radio	V	V																		V	V																																			
U	2005	ALL	Body	Right Power Sliding Door Module	V	V																		V	V																																			
U	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V																												
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module	V	V																		V											V	V																								
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V															V												
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module	V	V																		V											V	V																								
U	2006	ALL	Chassis	Electronic Brake Control Module	V	V																		V																																				
U	2006	ALL	Body	Body Control Module	V	V																		V	V																																			
U	2006	ALL	Body	Disc Player and Video	V																				V																																				
U	2006	ALL	Body	Digital Radio Receiver	V	V																			V																																				
U	2006	ALL	Body	HVAC Control Module	V	V																		V																																				
U	2006	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
U	2006	ALL	Body	Left Power Sliding Door Module	V	V																		V	V																																			
U	2006	ALL	Body	Mobile Digital Media	V																																																						
U	2006	ALL	Body	Navigation Radio	V	V																		V	V																																			
U	2006	ALL	Body	Navigation Radio	V	V																		V																																				
U	2006	ALL	Body	Radio	V	V																		V	V																																			
U	2006	ALL	Body	Right Power Sliding Door Module	V	V																		V	V																																			
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V															V												
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module	V	V																		V											V	V																								
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V															V												
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module	V	V																		V											V	V																								
U	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V																																				
U	2007	ALL	Body	Body Control Module	V	V																		V	V																																			
U	2007	ALL	Body	Digital Radio Receiver	V	V																			V																																				
U	2007	ALL	Body	Disc Player and Video Display	V																				V																																				
U	2007	ALL	Body	HVAC Control Module	V	V																		V																																				
U	2007	ALL	Body	Left Power Sliding Door Module	V	V																		V	V																																			
U	2007	ALL	Body	Mobile Digital Media	V																																																						
U	2007	ALL	Body	Radio	V	V																		V	V																																			
U	2007	ALL	Body	Navigation Radio	V	V																		V	V																																			
U	2007	ALL	Body	Right Power Sliding Door Module	V	V																		V	V																																			
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V															V												
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module	V	V																		V											V	V																								
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V															V												
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module	V	V																		V											V	V																								
U	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V																																				
U	2008	ALL	Body	Body Control Module	V	V																		V	V																																			
U	2008	ALL	Body	Digital Radio Receiver	V	V																			V																																				
U	2008	ALL	Body	Disc Player and Video Display	V																				V																																				
U	2008	ALL	Body	C60 Single Zone HVAC Manual	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual	V	V																		V																																					
U	2008	ALL	Body	Left Power Sliding Door Module	V	V																		V	V																																				
U	2008	ALL	Body	Radio	V	V																			V																																				
U	2008	ALL	Body	Navigation Radio	V	V																		V	V																																				
U	2008	ALL	Body	Remote Control Door Lock Receiver	V	V																			V																																				
U	2008	ALL	Body	Right Power Sliding Door Module	V	V																		V	V																																				
U	2009	ALL	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V													
U	2009	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																								
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM	V	V																		V																																				
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM	V	V																		V																																				
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM	V	V																		V																																				
U	2009	ALL	Body	Body Control Module	V	V																		V	V																																				
U	2009	ALL	Body	Digital Radio Receiver	V	V																		V	V																																				
U	2009	ALL	Body	Disc Player and Video Display	V																				V																																				
U	2009	ALL	Body	C60 Single Zone HVAC Manual	V	V																		V																																				
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual	V	V																		V																																				
U	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																				
U	2009	ALL	Body	Left Power Sliding Door Module	V	V																		V	V																																				
U	2009	ALL	Body	Radio	V	V																			V																																				
U	2009	ALL	Body	Remote Control Door Lock Receiver	V	V																			V																																				
U	2009	ALL	Body	Right Power Sliding Door Module	V	V																		V	V																																				
V	2004	ALL	Powertrain	Engine Data Display	V	V							V			V					V			V	V							V																													
V	2004	ALL	Powertrain	Transmission Data Display	V	V																		V											V	V																								
V	2004	ALL	Body	Digital Radio Receiver	V	V																			V																																				
V	2004	ALL	Body	Driver Information Center	V																																																						
V	2004	ALL	Body	Instrument Panel Cluster	V	V																		V																																				
V	2004	ALL	Body	Radio	V	V																		V																																				
V	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
V	2004	ALL	Body	Vehicle Theft Deterrent	V	V																																																					
V	2005	Venture	Powertrain	Engine Control Module	V	V							V			V					V			V	V							V																													
V	2005	Venture	Powertrain	Transmission Control Module	V	V																		V											V	V																								
V	2005	Venture	Body	Digital Radio Receiver	V	V																			V																																				
V	2005	Venture	Body	Driver Information Center	V																																																						
V	2005	Venture	Body	Instrument Panel Cluster	V	V																		V																																				
V	2005	Venture	Body	Radio	V	V																		V																																				
V	2005	Venture	Body	Supplemental Inflatable Restraint	V	V																																																					
V	2005	Venture	Body	Vehicle Theft Deterrent	V	V																																																					
V	2005	Uplander	Powertrain	Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V																													
V	2005	Uplander	Powertrain	Transmission Control Module	V	V																		V											V	V																								
V	2005	Uplander	Chassis	Electronic Brake Control Module	V	V																		V																																				
V	2005	Uplander	Body	Body Control Module	V	V																		V	V																																				
V	2005	Uplander	Body	Disc Player and Video	V																				V																																				
V	2005	Uplander	Body	Digital Radio Receiver	V	V																			V																																				
V	2005	Uplander	Body	HVAC Control Module	V	V																		V																																				
V	2005	Uplander	Body	Instrument Panel Cluster	V	V																		V	V																																				
V	2005	Uplander	Body	Left Power Sliding Door Module	V	V																		V	V																																				
V	2005	Uplander	Body	Mobile Digital Media	V																																																						
V	2005	Uplander	Body	Navigation Radio	V	V																		V	V																																				
V	2005	Uplander	Body	Navigation Radio	V	V																		V																																				
V	2005	Uplander	Body	Radio	V	V																		V	V																																			
V	2005	Uplander	Body	Right Power Sliding Door Module	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
V	2005	Uplander	Body	Supplemental Inflatable Restraint	V	V																																																									
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V																															
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module	V	V																		V											V	V																											
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V																	
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module	V	V																		V											V	V																											
V	2006	ALL	Chassis	Electronic Brake Control Module	V	V																		V																																							
V	2006	ALL	Body	Body Control Module	V	V																		V	V																																					
V	2006	ALL	Body	Disc Player and Video	V																				V																																					
V	2006	ALL	Body	Digital Radio Receiver	V	V																			V																																					
V	2006	ALL	Body	HVAC Control Module	V	V																		V																																					
V	2006	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																					
V	2006	ALL	Body	Left Power Sliding Door Module	V	V																		V	V																																					
V	2006	ALL	Body	Mobile Digital Media	V																																																								
V	2006	ALL	Body	Navigation Radio	V	V																		V	V																																					
V	2006	ALL	Body	Navigation Radio	V	V																		V																																					
V	2006	ALL	Body	Radio	V	V																		V	V																																					
V	2006	ALL	Body	Right Power Sliding Door Module	V	V																		V	V																																					
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V																	
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module	V	V																		V											V	V																											
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V																	
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module	V	V																		V											V	V																											
V	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V																																							
V	2007	ALL	Body	Body Control Module	V	V																		V	V																																					
V	2007	ALL	Body	Digital Radio Receiver	V	V																			V																																					
V	2007	ALL	Body	Disc Player and Video Display	V																				V																																					
V	2007	ALL	Body	HVAC Control Module	V	V																		V																																					
V	2007	ALL	Body	Left Power Sliding Door Module	V	V																		V	V																																					
V	2007	ALL	Body	Mobile Digital Media	V																																																								
V	2007	ALL	Body	Radio	V	V																		V	V																																					
V	2007	ALL	Body	Navigation Radio	V	V																		V	V																																					
V	2007	ALL	Body	Right Power Sliding Door Module	V	V																		V	V																																					
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V																	
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module	V	V																		V											V	V																											
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V																	
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module	V	V																		V											V	V																											
V	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V																																							
V	2008	ALL	Body	Body Control Module	V	V																		V	V																																					
V	2008	ALL	Body	Digital Radio Receiver	V	V																			V																																					
V	2008	ALL	Body	Disc Player and Video Display	V																				V																																					
V	2008	ALL	Body	C60 Single Zone HVAC Manual	V	V																		V																																							
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual	V	V																		V																																							
V	2008	ALL	Body	Left Power Sliding Door Module	V	V																		V	V																																					
V	2008	ALL	Body	Radio	V	V																			V																																					
V	2008	ALL	Body	Navigation Radio	V	V																		V	V																																					
V	2008	ALL	Body	Remote Control Door Lock Receiver	V	V																			V																																					
V	2008	ALL	Body	Right Power Sliding Door Module	V	V																		V	V																																					
V	2009	ALL	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V																	
V	2009	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																											
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM	V	V																		V																																							
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM	V	V																		V																																							
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM	V	V																		V																																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
V	2009	ALL	Body	Body Control Module	V	V																		V	V																																			
V	2009	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
V	2009	ALL	Body	Disc Player and Video Display	V																				V																																			
V	2009	ALL	Body	C60 Single Zone HVAC Manual	V	V																		V																																			
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual	V	V																		V																																			
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster	V	V																		V	V																																		
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster	V	V																		V	V																																		
V	2009	ALL	Body	Left Power Sliding Door Module	V	V																		V	V																																		
V	2009	ALL	Body	Radio	V	V																			V																																		
V	2009	ALL	Body	Remote Control Door Lock Receiver	V	V																			V																																		
V	2009	ALL	Body	Right Power Sliding Door Module	V	V																		V	V																																		
X	2004	ALL	Powertrain	Engine Control Module	V	V							V			V					V			V	V							V																												
X	2004	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																						
X	2004	ALL	Body	Digital Radio Receiver	V	V																			V																																		
X	2004	ALL	Body	Driver Information Center	V																																																					
X	2004	ALL	Body	Instrument Panel Cluster	V	V																		V																																		
X	2004	ALL	Body	Radio	V	V																		V																																		
X	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
X	2004	ALL	Body	Vehicle Theft Deterrent	V	V																																																				
X	2005	ALL	Powertrain	Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V																											
X	2005	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V																						
X	2005	ALL	Chassis	Electronic Brake Control Module	V	V																		V																																		
X	2005	ALL	Body	Body Control Module	V	V																		V	V																																		
X	2005	ALL	Body	Disc Player and Video	V																				V																																		
X	2005	ALL	Body	Digital Radio Receiver	V	V																			V																																		
X	2005	ALL	Body	HVAC Control Module	V	V																		V																																		
X	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
X	2005	ALL	Body	Left Power Sliding Door Module	V	V																		V	V																																		
X	2005	ALL	Body	Mobile Digital Media	V																																																					
X	2005	ALL	Body	Navigation Radio	V	V																		V	V																																		
X	2005	ALL	Body	Navigation Radio	V	V																		V																																		
X	2005	ALL	Body	Radio	V	V																		V	V																																		
X	2005	ALL	Body	Right Power Sliding Door Module	V	V																		V	V																																		
X	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V																											
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module	V	V																		V											V	V																						
X	2006	ALL	Chassis	Electronic Brake Control Module	V	V																		V																																		
X	2006	ALL	Body	Body Control Module	V	V																		V	V																																		
X	2006	ALL	Body	Disc Player and Video	V																				V																																		
X	2006	ALL	Body	Digital Radio Receiver	V	V																			V																																		
X	2006	ALL	Body	HVAC Control Module	V	V																		V																																		
X	2006	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
X	2006	ALL	Body	Left Power Sliding Door Module	V	V																		V	V																																		
X	2006	ALL	Body	Mobile Digital Media	V																																																					
X	2006	ALL	Body	Navigation Radio	V	V																		V	V																																		
X	2006	ALL	Body	Navigation Radio	V	V																		V																																		
X	2006	ALL	Body	Radio	V	V																		V	V																																		
X	2006	ALL	Body	Right Power Sliding Door Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2006	ALL	Powertrain	Transmission Control Module																																																										
A	2006	ALL	Chassis	Electronic Brake Control Module																																																										
A	2006	ALL	Chassis	Power Steering Control Module																																																										
A	2006	ALL	Body	Body Control Module																																																									
A	2006	ALL	Body	Digital Radio Receiver																																																									
A	2006	ALL	Body	Instrument Panel Cluster																																																									
A	2006	ALL	Body	Radio																																																									
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2006	ALL	Body	Theft Deterrent Module																																																									
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																										
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
A	2007	ALL	Chassis	Electronic Brake Control Module																																																										
A	2007	ALL	Chassis	Power Steering Control Module																																																										
A	2007	ALL	Body	Body Control Module																																																									
A	2007	ALL	Body	Digital Radio Receiver																																																									
A	2007	ALL	Body	Instrument Panel Cluster																																																									
A	2007	ALL	Body	Radio																																																									
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2007	ALL	Body	Theft Deterrent Module																																																									
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																										
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2008	HHR	Chassis	Power Steering Control Module																																																										
A	2008	HHR	Chassis	Power Steering Control Module																																																										
A	2008	HHR	Body	Body Control Module																																																									
A	2008	HHR	Body	Digital Radio Receiver																																																									
A	2008	HHR	Body	Instrument Panel Cluster																																																									
A	2008	HHR	Body	Radio																																																									
A	2008	HHR	Body	Supplemental Inflatable Restraint																																																									
A	2008	HHR	Body	Theft Deterrent Module																																																									
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																										
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2008	HHR Panel	Body	Body Control Module																																																										
A	2008	HHR Panel	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2008	HHR Panel	Body	Radio																																																										
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2008	HHR Panel	Body	Theft Deterrent Module																																																										
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																																										
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2009	HHR	Chassis	Power Steering Control Module																																																										
A	2009	HHR	Chassis	Power Steering Control Module																																																										
A	2009	HHR	Body	Body Control Module																																																										
A	2009	HHR	Body	Digital Radio Receiver																																																										
A	2009	HHR	Body	Instrument Panel Cluster																																																										
A	2009	HHR	Body	Radio																																																										
A	2009	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2009	HHR	Body	Theft Deterrent Module																																																										
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2009	HHR Panel	Body	Body Control Module																																																										
A	2009	HHR Panel	Body	Digital Radio Receiver																																																										
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2009	HHR Panel	Body	Radio																																																										
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2009	HHR Panel	Body	Theft Deterrent Module																																																										
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																										
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2010	HHR	Chassis	Power Steering Control Module																																																										
A	2010	HHR	Chassis	Power Steering Control Module																																																										
A	2010	HHR	Body	Body Control Module																																																										
A	2010	HHR	Body	Digital Radio Receiver																																																										
A	2010	HHR	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2010	HHR	Body	Radio																																																												
A	2010	HHR	Body	Supplemental Inflatable Restraint																																																												
A	2010	HHR	Body	Theft Deterrent Module																																																												
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																												
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																												
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																												
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																												
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																												
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																												
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																												
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2010	HHR Panel	Body	Body Control Module																																																												
A	2010	HHR Panel	Body	Digital Radio Receiver																																																												
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																												
A	2010	HHR Panel	Body	Radio																																																												
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																																												
A	2010	HHR Panel	Body	Theft Deterrent Module																																																												
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																												
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																												
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																												
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																												
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																																												
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2011	HHR	Chassis	Power Steering Control Module																																																												
A	2011	HHR	Body	Body Control Module																																																												
A	2011	HHR	Body	Digital Radio Receiver																																																												
A	2011	HHR	Body	Instrument Panel Cluster																																																												
A	2011	HHR	Body	Radio																																																												
A	2011	HHR	Body	Supplemental Inflatable Restraint																																																												
A	2011	HHR	Body	Theft Deterrent Module																																																												
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																												
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																												
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																												
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																												
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																												
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2011	HHR Panel	Body	Body Control Module																																																												
A	2011	HHR Panel	Body	Digital Radio Receiver																																																												
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																												
A	2011	HHR Panel	Body	Radio																																																												
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																																												
A	2011	HHR Panel	Body	Theft Deterrent Module																																																												
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																				V																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																				V																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																				V																																							
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																				V																																							
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																											
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																							
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																				V																																							
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																				V																																							
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																											
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																											
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																				V																																							
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																				V																																							
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																				V																																							
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																											
A	2013	Trax	Chassis	Electronic Brake Control Module																																																											
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2013	Trax	Chassis	Power Steering Control Module																																																											
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module				V	V																																																						
A	2013	Trax	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V	V	V	V																												V						
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
A	2013	Trax	Body	Passenger Presence Module																																V																											
A	2013	Trax	Body	Instrument Cluster																																	V																								
A	2013	Trax	Body	Radio																																																										
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																			
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																											V												
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V												
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																											V												
A	2013	Trax	Body	Front Seat Heating Control Module																																					V	V																		
A	2013	Trax	Body	Parking Assist Control Module																																V																								
A	2013	Trax	Body	Frontview Camera Module																																																								
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																						
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																									
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																								
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																				V																																				
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																								
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																								
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																								
A	2014	Trax	Chassis	Electronic Brake Control Module																																																								
A	2014	Trax	Chassis	Power Steering Control Module																																																								
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
A	2014	Trax	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V	V	V	V																									V						
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
A	2014	Trax	Body	Passenger Presence Module																																V																							
A	2014	Trax	Body	Instrument Cluster																																	V																					
A	2014	Trax	Body	Radio																																																							
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V	V																	
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																											V									
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V									
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																											V									
A	2014	Trax	Body	Front Seat Heating Control Module																																					V	V																
A	2014	Trax	Body	Parking Assist Control Module																																V																					
A	2014	Trax	Body	Frontview Camera Module																																																						
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																			
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																							
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																							
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																			
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																							
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																							
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																			
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																							
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																							
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																							
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																							
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																							
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																							
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																							
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																							
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																							
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																							
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																							
A	2015	Trax	Powertrain	Chassis Control Module																																																							
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																							
A	2015	Trax	Chassis	Electronic Brake Control Module																																																							
A	2015	Trax	Chassis	Power Steering Control Module																																																							
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
A	2015	Trax	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V	V	V	V																									V						
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
A	2015	Trax	Body	Passenger Presence Module																																V																							
A	2015	Trax	Body	Instrument Cluster																																	V																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2015	Trax	Body	Radio																																																								
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																		V	V	V																				
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																											V													
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V													
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																											V													
A	2015	Trax	Body	Seat Memory Control Module																																																								
A	2015	Trax	Body	Front Seat Heating Control Module																																					V	V																		
A	2015	Trax	Body	Right Side Object Detection Control Module																																																								
A	2015	Trax	Body	Left Side Object Detection Control Module																																																								
A	2015	Trax	Body	Parking Assist Control Module																																V																								
A	2015	Trax	Body	Frontview Camera Module																																																								
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																				V																																				
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																				V																																				
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																								
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																				V																																				
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																								
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																				
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																				
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																								
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																				V																																				
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																								
A	2016	Trax	Powertrain	Chassis Control Module																																																								
A	2016	Trax	Chassis	Electronic Brake Control Module																																																								
A	2016	Trax	Chassis	Power Steering Control Module																																																								
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
A	2016	Trax	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V	V	V	V																										V						
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
A	2016	Trax	Body	Passenger Presence Module																																V																								
A	2016	Trax	Body	Instrument Cluster																																	V																							
A	2016	Trax	Body	Trailer Interface Control Module																																	V																							
A	2016	Trax	Body	Radio																																																								
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																		V	V	V																				
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																											V													
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																											V													
A	2016	Trax	Body	Seat Memory Control Module																																																								
A	2016	Trax	Body	Front Seat Heating Control Module																																					V	V																		
A	2016	Trax	Body	Right Side Object Detection Control Module																																																								
A	2016	Trax	Body	Left Side Object Detection Control Module																																																								
A	2016	Trax	Body	Parking Assist Control Module																																V																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2016	Trax	Body	Frontview Camera Module																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																								
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																								
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																								
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																								
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																								
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
C	2004	ALL	Chassis	ESC																																																								
C	2004	ALL	Chassis	Rear Wheel Steering																																																								
C	2004	ALL	Chassis	Tire Pressure Monitor																																																								
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																								
C	2004	ALL	Chassis	VSES																																																								
C	2004	ALL	Body	Amplifier (Bose)																																																								
C	2004	ALL	Body	Body Control Module																														V																										
C	2004	ALL	Body	CD Changer																																																								
C	2004	ALL	Body	Chime																																																								
C	2004	ALL	Body	Driver Door Module																																																								
C	2004	ALL	Body	Driver Seat Module																																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																								
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
C	2004	ALL	Body	Instrument Panel Cluster																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2004	ALL	Body	OnStar																																	V																							
C	2004	ALL	Body	Passenger Door Module																																																								
C	2004	ALL	Body	Passenger Presence System																																																								
C	2004	ALL	Body	Radio Base																																																								
C	2004	ALL	Body	Radio Uplevel																																																								
C	2004	ALL	Body	Radio Navigation																																																								
C	2004	ALL	Body	Rear Aux. Climate Module																																																								
C	2004	ALL	Body	Rear HVAC																																																								
C	2004	ALL	Body	Rear Seat Audio																																																								
C	2004	ALL	Body	Rear Seat Entertainment																																																								
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2004	ALL	Body	Vehicle Theft Deterrent																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																								
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																								
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																								
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																								
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																							
C	2005	ALL	Chassis	ESC																																																							
C	2005	ALL	Chassis	Rear Wheel Steering																																																								
C	2005	ALL	Chassis	Tire Pressure Monitor																																																								
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2005	ALL	Chassis	VSES																																																									
C	2005	ALL	Body	Amplifier (Bose)																																																										
C	2005	ALL	Body	Body Control Module																														V																												
C	2005	ALL	Body	CD Changer																																																									
C	2005	ALL	Body	Chime																																																									
C	2005	ALL	Body	Disc Player and Video Display																																																									
C	2005	ALL	Body	Driver Door Module																																																									
C	2005	ALL	Body	Driver Seat Module																																																									
C	2005	ALL	Body	Generator Battery Control Module																																																									
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2005	ALL	Body	Instrument Panel Cluster																																																										
C	2005	ALL	Body	Passenger Door Module																																																										
C	2005	ALL	Body	Passenger Presence System																																																										
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio																																																										
C	2005	ALL	Body	Rear Aux. Climate Module																																																										
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Body	Vehicle Comm. Interface Module																																	V																										
C	2005	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																										
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																									
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																									
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																														V																												
C	2006	ALL	Body	CD Changer																																																									
C	2006	ALL	Body	Chime																																																									
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																										
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																	V																									
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																									
C	2007	Avalanche	Body	Amplifier (Bose)																																																										
C	2007	Avalanche	Body	Assist Step Controller																																																										
C	2007	Avalanche	Body	Body Control Module																																																										
C	2007	Avalanche	Body	Body Control Module (aux.)																																																										
C	2007	Avalanche	Body	Digital Radio Receiver																																																										
C	2007	Avalanche	Body	Driver Door Switch																																																										
C	2007	Avalanche	Body	HVAC Control Module Auto																																												V														
C	2007	Avalanche	Body	HVAC Control Module Manual																																												V														
C	2007	Avalanche	Body	Instrument Panel Cluster																																																										
C	2007	Avalanche	Body	Memory Seat Module																																																										
C	2007	Avalanche	Body	Park Assist Module																																																										
C	2007	Avalanche	Body	Passenger Door Switch																																																										
C	2007	Avalanche	Body	Passenger Presence System																																																										
C	2007	Avalanche	Body	Radio																																																										
C	2007	Avalanche	Body	Rear Heated Seat Module																																																										
C	2007	Avalanche	Body	Rear HVAC/RSA																																																										
C	2007	Avalanche	Body	Rollover Sensor																																																										
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2007	Avalanche	Body	Theft Deterrent Module																																																										
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Suburban	Chassis	Electronic Suspension Control																																																										
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																										
C	2007	Suburban	Body	Amplifier (Bose)																																																										
C	2007	Suburban	Body	Assist Step Controller																																																										
C	2007	Suburban	Body	Body Control Module																																																										
C	2007	Suburban	Body	Body Control Module (aux.)																																																										
C	2007	Suburban	Body	Digital Radio Receiver																																																										
C	2007	Suburban	Body	Driver Door Switch																																																										
C	2007	Suburban	Body	HVAC Control Module Auto																																												V														
C	2007	Suburban	Body	HVAC Control Module Manual																																												V														
C	2007	Suburban	Body	Instrument Panel Cluster																																																										
C	2007	Suburban	Body	Lift Gate Module																																																										
C	2007	Suburban	Body	Memory Seat Module																																																										
C	2007	Suburban	Body	Park Assist Module																																																										
C	2007	Suburban	Body	Passenger Door Switch																																																										
C	2007	Suburban	Body	Passenger Presence System																																																										
C	2007	Suburban	Body	Radio																																																										
C	2007	Suburban	Body	Rear Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2007	Suburban	Body	Rear HVAC/RSA																																																									
C	2007	Suburban	Body	Rollover Sensor																																																									
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																																									
C	2007	Suburban	Body	Theft Deterrent Module																																																									
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2007	Silverado	Chassis	Electronic Suspension Control																																																									
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																									
C	2007	Silverado	Body	Amplifier (Bose)																																																									
C	2007	Silverado	Body	Body Control Module																																																									
C	2007	Silverado	Body	Body Control Module (aux.)																																																									
C	2007	Silverado	Body	Digital Radio Receiver																																																									
C	2007	Silverado	Body	Driver Door Switch																																																									
C	2007	Silverado	Body	HVAC Control Module Auto																																												V														
C	2007	Silverado	Body	HVAC Control Module Manual																																												V														
C	2007	Silverado	Body	Instrument Panel Cluster																																																									
C	2007	Silverado	Body	Memory Seat Module																																																									
C	2007	Silverado	Body	Park Assist Module																																																									
C	2007	Silverado	Body	Passenger Door Switch																																																									
C	2007	Silverado	Body	Passenger Presence System																																																									
C	2007	Silverado	Body	Radio																																																									
C	2007	Silverado	Body	Rear Heated Seat Module																																																									
C	2007	Silverado	Body	Rear HVAC/RSA																																																									
C	2007	Silverado	Body	Rollover Sensor																																																									
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																																									
C	2007	Silverado	Body	Theft Deterrent Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2007	Tahoe	Body	Amplifier (Bose)																																																										
C	2007	Tahoe	Body	Assist Step Controller																																																										
C	2007	Tahoe	Body	Body Control Module																																																										
C	2007	Tahoe	Body	Body Control Module (aux.)																																																										
C	2007	Tahoe	Body	Digital Radio Receiver																																																										
C	2007	Tahoe	Body	Driver Door Switch																																																										
C	2007	Tahoe	Body	HVAC Control Module Auto																																												V														
C	2007	Tahoe	Body	HVAC Control Module Manual																																												V														
C	2007	Tahoe	Body	Instrument Panel Cluster																																																										
C	2007	Tahoe	Body	Lift Gate Module																																																										
C	2007	Tahoe	Body	Memory Seat Module																																																										
C	2007	Tahoe	Body	Park Assist Module																																																										
C	2007	Tahoe	Body	Passenger Door Switch																																																										
C	2007	Tahoe	Body	Passenger Presence System																																																										
C	2007	Tahoe	Body	Radio																																																										
C	2007	Tahoe	Body	Rear Heated Seat Module																																																										
C	2007	Tahoe	Body	Rear HVAC/RSA																																																										
C	2007	Tahoe	Body	Rollover Sensor																																																										
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2007	Tahoe	Body	Theft Deterrent Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2008	Avalanche	Body	Amplifier (Bose)																																																										
C	2008	Avalanche	Body	Assist Step Controller																																																										
C	2008	Avalanche	Body	Body Control Module																																																										
C	2008	Avalanche	Body	Body Control Module (aux.)																																																										
C	2008	Avalanche	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2008	Avalanche	Body	Driver Door Switch																																																									
C	2008	Avalanche	Body	HVAC Control Module Auto																																												V												
C	2008	Avalanche	Body	HVAC Control Module Manual																																												V												
C	2008	Avalanche	Body	Instrument Panel Cluster																																																								
C	2008	Avalanche	Body	Memory Seat Module																																																								
C	2008	Avalanche	Body	Park Assist Module																																																								
C	2008	Avalanche	Body	Passenger Door Switch																																																								
C	2008	Avalanche	Body	Passenger Presence System																																																								
C	2008	Avalanche	Body	Radio																																																								
C	2008	Avalanche	Body	Rear Heated Seat Module																																																								
C	2008	Avalanche	Body	Rear HVAC/RSA																																																								
C	2008	Avalanche	Body	Rollover Sensor																																																								
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																								
C	2008	Avalanche	Body	Theft Deterrent Module																																																								
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2008	Suburban	Chassis	Electronic Suspension Control																																																								
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																								
C	2008	Suburban	Body	Amplifier (Bose)																																																								
C	2008	Suburban	Body	Assist Step Controller																																																								
C	2008	Suburban	Body	Body Control Module																																																								
C	2008	Suburban	Body	Body Control Module (aux.)																																																								
C	2008	Suburban	Body	Digital Radio Receiver																																																								
C	2008	Suburban	Body	Driver Door Switch																																																								
C	2008	Suburban	Body	HVAC Control Module Auto																																												V												
C	2008	Suburban	Body	HVAC Control Module Manual																																												V												
C	2008	Suburban	Body	Instrument Panel Cluster																																																								
C	2008	Suburban	Body	Lift Gate Module																																																								
C	2008	Suburban	Body	Memory Seat Module																																																								
C	2008	Suburban	Body	Park Assist Module																																																								
C	2008	Suburban	Body	Passenger Door Switch																																																								
C	2008	Suburban	Body	Passenger Presence System																																																								
C	2008	Suburban	Body	Radio																																																								
C	2008	Suburban	Body	Rear Heated Seat Module																																																								
C	2008	Suburban	Body	Rear HVAC/RSA																																																								
C	2008	Suburban	Body	Rollover Sensor																																																								
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2008	Suburban	Body	Theft Deterrent Module																																																								
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2008	Silverado	Chassis	Electronic Suspension Control																																																								
C	2008	Silverado	Chassis	Trailer Brake Control Module																																																								
C	2008	Silverado	Body	Amplifier (Bose)																																																								
C	2008	Silverado	Body	Body Control Module																																																								
C	2008	Silverado	Body	Body Control Module (aux.)																																																								
C	2008	Silverado	Body	Digital Radio Receiver																																																								
C	2008	Silverado	Body	Driver Door Switch																																																								
C	2008	Silverado	Body	HVAC Control Module Auto																																																								
C	2008	Silverado	Body	HVAC Control Module Manual																																																								
C	2008	Silverado	Body	Instrument Panel Cluster																																																								
C	2008	Silverado	Body	Memory Seat Module																																																								
C	2008	Silverado	Body	Park Assist Module																																																								
C	2008	Silverado	Body	Passenger Door Switch																																																								
C	2008	Silverado	Body	Passenger Presence System																																																								
C	2008	Silverado	Body	Radio																																																								
C	2008	Silverado	Body	Rear Heated Seat Module																																																								
C	2008	Silverado	Body	Rear HVAC/RSA																																																								
C	2008	Silverado	Body	Rollover Sensor																																																								
C	2008	Silverado	Body	Supplemental Inflatable Restraint																																																								
C	2008	Silverado	Body	Theft Deterrent Module																																																								
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																																								
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																												
C	2008	Tahoe	Body	Amplifier (Bose)																																																												
C	2008	Tahoe	Body	Assist Step Controller																																																												
C	2008	Tahoe	Body	Body Control Module																																																												
C	2008	Tahoe	Body	Body Control Module (aux.)																																																												
C	2008	Tahoe	Body	Digital Radio Receiver																																																												
C	2008	Tahoe	Body	Driver Door Switch																																																												
C	2008	Tahoe	Body	HVAC Control Module Auto																																												V																
C	2008	Tahoe	Body	HVAC Control Module Manual																																												V																
C	2008	Tahoe	Body	Instrument Panel Cluster																																																												
C	2008	Tahoe	Body	Memory Seat Module																																																												
C	2008	Tahoe	Body	Park Assist Module																																																												
C	2008	Tahoe	Body	Passenger Presence System																																																												
C	2008	Tahoe	Body	Radio																																																												
C	2008	Tahoe	Body	Rear Heated Seat Module																																																												
C	2008	Tahoe	Body	Rear HVAC/RSA																																																												
C	2008	Tahoe	Body	Rollover Sensor																																																												
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2008	Tahoe	Body	Theft Deterrent Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2008	Tahoe Hybrid	Body	Body Control Module																																																												
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2008	Tahoe Hybrid	Body	HVAC Control Module																																												V																
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2008	Tahoe Hybrid	Body	Memory Seat Module																																																												
C	2008	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2008	Tahoe Hybrid	Body	Radio																																																										
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																																										
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2009	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2009	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2009	Avalanche	Body	Amplifier (Bose)																																																										
C	2009	Avalanche	Body	Assist Step Controller																																																										
C	2009	Avalanche	Body	Body Control Module																																																										
C	2009	Avalanche	Body	Body Control Module (aux.)																																																										
C	2009	Avalanche	Body	Digital Radio Receiver																																																										
C	2009	Avalanche	Body	Driver Door Switch																																																										
C	2009	Avalanche	Body	HVAC Control Module Auto																																																										
C	2009	Avalanche	Body	HVAC Control Module Manual																																																										
C	2009	Avalanche	Body	Instrument Panel Cluster																																																										
C	2009	Avalanche	Body	Memory Seat Module																																																										
C	2009	Avalanche	Body	Park Assist Module																																																										
C	2009	Avalanche	Body	Passenger Door Switch																																																										
C	2009	Avalanche	Body	Passenger Presence System																																																										
C	2009	Avalanche	Body	Radio																																																										
C	2009	Avalanche	Body	Rear Heated Seat Module																																																										
C	2009	Avalanche	Body	Rear HVAC/RSA																																																										
C	2009	Avalanche	Body	Rollover Sensor																																																										
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2009	Avalanche	Body	Theft Deterrent Module																																																										
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																									
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																									
C	2009	Cheyenne	Body	Amplifier (Bose)																																																									
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																									
C	2009	Cheyenne	Body	Digital Radio Receiver																																																									
C	2009	Cheyenne	Body	Driver Door Switch																																																									
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																									
C	2009	Cheyenne	Body	Park Assist Module																																																									
C	2009	Cheyenne	Body	Passenger Door Switch																																																									
C	2009	Cheyenne	Body	Passenger Presence System																																																									
C	2009	Cheyenne	Body	Rear Heated Seat Module																																																									
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																									
C	2009	Cheyenne	Body	Rollover Sensor																																																									
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																									
C	2009	Cheyenne	Body	Theft Deterrent Module																																																									
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
C	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																									
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2009	Suburban	Chassis	Electronic Suspension Control																																																									
C	2009	Suburban	Chassis	Trailer Brake Control Module																																																									
C	2009	Suburban	Body	Amplifier (Bose)																																																									
C	2009	Suburban	Body	Assist Step Controller																																																									
C	2009	Suburban	Body	Body Control Module																																																									
C	2009	Suburban	Body	Body Control Module (aux.)																																																									
C	2009	Suburban	Body	Digital Radio Receiver																																																									
C	2009	Suburban	Body	Driver Door Switch																																																									
C	2009	Suburban	Body	HVAC Control Module Auto																																												V													
C	2009	Suburban	Body	HVAC Control Module Manual																																												V													
C	2009	Suburban	Body	Instrument Panel Cluster																																																									
C	2009	Suburban	Body	Left Side Object Detection Module																																																									
C	2009	Suburban	Body	Lift Gate Module																																																									
C	2009	Suburban	Body	Memory Seat Module																																																									
C	2009	Suburban	Body	Park Assist Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2009	Suburban	Body	Passenger Door Switch																																																									
C	2009	Suburban	Body	Passenger Presence System																																																									
C	2009	Suburban	Body	Radio																																																									
C	2009	Suburban	Body	Rear Heated Seat Module																																																									
C	2009	Suburban	Body	Rear HVAC/RSA																																																									
C	2009	Suburban	Body	Right Side Object Detection Module																																																									
C	2009	Suburban	Body	Rollover Sensor																																																									
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																																									
C	2009	Suburban	Body	Theft Deterrent Module																																																									
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																									
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																									
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																									
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																									
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																									
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																									
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
C	2009	Silverado	Chassis	Electronic Suspension Control																																																									
C	2009	Silverado	Chassis	Trailer Brake Control Module																																																									
C	2009	Silverado	Body	Amplifier (Bose)																																																									
C	2009	Silverado	Body	Body Control Module																																																									
C	2009	Silverado	Body	Body Control Module (aux.)																																																									
C	2009	Silverado	Body	Digital Radio Receiver																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2009	Silverado	Body	Driver Door Switch																																																								
C	2009	Silverado	Body	HVAC Control Module Auto																																												V												
C	2009	Silverado	Body	HVAC Control Module Manual																																												V												
C	2009	Silverado	Body	Instrument Panel Cluster																																																								
C	2009	Silverado	Body	Memory Seat Module																																																								
C	2009	Silverado	Body	Park Assist Module																																																								
C	2009	Silverado	Body	Passenger Door Switch																																																								
C	2009	Silverado	Body	Passenger Presence System																																																								
C	2009	Silverado	Body	Radio																																																								
C	2009	Silverado	Body	Rear Heated Seat Module																																																								
C	2009	Silverado	Body	Rear HVAC/RSA																																																								
C	2009	Silverado	Body	Rollover Sensor																																																								
C	2009	Silverado	Body	Supplemental Inflatable Restraint																																																								
C	2009	Silverado	Body	Theft Deterrent Module																																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																								
C	2009	Silverado Hybrid	Body	Body Control Module																																																								
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																								
C	2009	Silverado Hybrid	Body	Driver Door Switch																																																								
C	2009	Silverado Hybrid	Body	HVAC Control Module																																												V												
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
C	2009	Silverado Hybrid	Body	Memory Seat Module																																																								
C	2009	Silverado Hybrid	Body	Park Assist Module																																																								
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																																								
C	2009	Silverado Hybrid	Body	Passenger Presence System																																																								
C	2009	Silverado Hybrid	Body	Radio																																																								
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
C	2009	Silverado Hybrid	Body	Rollover Sensor																																																								
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																								
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																																												
C	2009	Tahoe	Body	Amplifier (Bose)																																																												
C	2009	Tahoe	Body	Assist Step Controller																																																												
C	2009	Tahoe	Body	Body Control Module																																																												
C	2009	Tahoe	Body	Body Control Module (aux.)																																																												
C	2009	Tahoe	Body	Digital Radio Receiver																																																												
C	2009	Tahoe	Body	Driver Door Switch																																																												
C	2009	Tahoe	Body	HVAC Control Module Auto																																												V															
C	2009	Tahoe	Body	HVAC Control Module Manual																																												V															
C	2009	Tahoe	Body	Instrument Panel Cluster																																																												
C	2009	Tahoe	Body	Left Side Object Detection Module																																																												
C	2009	Tahoe	Body	Lift Gate Module																																																												
C	2009	Tahoe	Body	Memory Seat Module																																																												
C	2009	Tahoe	Body	Park Assist Module																																																												
C	2009	Tahoe	Body	Passenger Door Switch																																																												
C	2009	Tahoe	Body	Passenger Presence System																																																												
C	2009	Tahoe	Body	Radio																																																											
C	2009	Tahoe	Body	Rear Heated Seat Module																																																												
C	2009	Tahoe	Body	Rear HVAC/RSA																																																												
C	2009	Tahoe	Body	Right Side Object Detection Module																																																												
C	2009	Tahoe	Body	Rollover Sensor																																																												
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2009	Tahoe	Body	Theft Deterrent Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2009	Tahoe Hybrid	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																																											
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																																											
C	2009	Tahoe Hybrid	Body	HVAC Control Module																																												V															
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
C	2009	Tahoe Hybrid	Body	Park Assist Module																																																											
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																											
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																																											
C	2009	Tahoe Hybrid	Body	Radio																																																											
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																											
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	Avalanche	Chassis	Electronic Brake Control Module																																																											
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																											
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Avalanche	Body	Amplifier (Bose)																																																											
C	2010	Avalanche	Body	Assist Step Controller																																																											
C	2010	Avalanche	Body	Body Control Module																																																											
C	2010	Avalanche	Body	Body Control Module (aux.)																																																											
C	2010	Avalanche	Body	Digital Radio Receiver																																																											
C	2010	Avalanche	Body	Driver Door Switch																																																											
C	2010	Avalanche	Body	HVAC Control Module Auto																																												V															
C	2010	Avalanche	Body	HVAC Control Module Manual																																												V															
C	2010	Avalanche	Body	Instrument Panel Cluster																																																											
C	2010	Avalanche	Body	Memory Seat Module																																																											
C	2010	Avalanche	Body	Park Assist Module																																																											
C	2010	Avalanche	Body	Passenger Door Switch																																																											
C	2010	Avalanche	Body	Passenger Presence System																																																											
C	2010	Avalanche	Body	Radio																																																											
C	2010	Avalanche	Body	Rear Heated Seat Module																																																											
C	2010	Avalanche	Body	Rear HVAC/RSA																																																											
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																									V	V																																
C	2010	Avalanche	Body	Theft Deterrent Module																																																											
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																									
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																									
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Cheyenne	Body	Amplifier (Bose)																																																									
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																									
C	2010	Cheyenne	Body	Digital Radio Receiver																																																									
C	2010	Cheyenne	Body	Driver Door Switch																																																									
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																									
C	2010	Cheyenne	Body	Park Assist Module																																																									
C	2010	Cheyenne	Body	Passenger Door Switch																																																									
C	2010	Cheyenne	Body	Passenger Presence System																																																									
C	2010	Cheyenne	Body	Rear Heated Seat Module																																																									
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																									
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																									V	V																															
C	2010	Cheyenne	Body	Theft Deterrent Module																																																									
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
C	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																									
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2010	Suburban	Chassis	Electronic Suspension Control																																																									
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Suburban	Body	Amplifier (Bose)																																																									
C	2010	Suburban	Body	Assist Step Controller																																																									
C	2010	Suburban	Body	Body Control Module																																																									
C	2010	Suburban	Body	Body Control Module (aux.)																																																									
C	2010	Suburban	Body	Digital Radio Receiver																																																									
C	2010	Suburban	Body	Driver Door Switch																																																									
C	2010	Suburban	Body	HVAC Control Module Auto																																												V														
C	2010	Suburban	Body	HVAC Control Module Manual																																												V														
C	2010	Suburban	Body	Instrument Panel Cluster																																																									
C	2010	Suburban	Body	Left Side Object Detection Module																																																									
C	2010	Suburban	Body	Lift Gate Module																																																									
C	2010	Suburban	Body	Memory Seat Module																																																									
C	2010	Suburban	Body	Park Assist Module																																																									
C	2010	Suburban	Body	Passenger Door Switch																																																									
C	2010	Suburban	Body	Passenger Presence System																																																									
C	2010	Suburban	Body	Radio																																																									
C	2010	Suburban	Body	Rear Heated Seat Module																																																									
C	2010	Suburban	Body	Rear HVAC/RSA																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2010	Suburban	Body	Right Side Object Detection Module																																																											
C	2010	Suburban	Body	Supplemental Inflatable Restraint																									V	V																																	
C	2010	Suburban	Body	Theft Deterrent Module																																																											
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																											
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																											
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2010	Silverado	Chassis	Electronic Suspension Control																																																											
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2010	Silverado	Body	Amplifier (Bose)																																																											
C	2010	Silverado	Body	Body Control Module																																																										
C	2010	Silverado	Body	Body Control Module (aux.)																																																											
C	2010	Silverado	Body	Digital Radio Receiver																																																											
C	2010	Silverado	Body	Driver Door Switch																																																											
C	2010	Silverado	Body	HVAC Control Module Auto																																												V																
C	2010	Silverado	Body	HVAC Control Module Manual																																												V																
C	2010	Silverado	Body	Instrument Panel Cluster																																																											
C	2010	Silverado	Body	Memory Seat Module																																																											
C	2010	Silverado	Body	Park Assist Module																																																											
C	2010	Silverado	Body	Passenger Door Switch																																																											
C	2010	Silverado	Body	Passenger Presence System																																																											
C	2010	Silverado	Body	Radio																																																											
C	2010	Silverado	Body	Rear Heated Seat Module																																																											
C	2010	Silverado	Body	Rear HVAC/RSA																																																											
C	2010	Silverado	Body	Supplemental Inflatable Restraint																									V	V																																	
C	2010	Silverado	Body	Theft Deterrent Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																								
C	2010	Silverado Hybrid	Body	Body Control Module																																																								
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																								
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																								
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																								
C	2010	Silverado Hybrid	Body	HVAC Control Module																																																								
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
C	2010	Silverado Hybrid	Body	Park Assist Module																																																								
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																								
C	2010	Silverado Hybrid	Body	Passenger Presence System																																																								
C	2010	Silverado Hybrid	Body	Radio																																																								
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																									V	V																														
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																								
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2010	Tahoe	Chassis	Electronic Brake Control Module																																																								
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																								
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Tahoe	Body	Amplifier (Bose)																																																								
C	2010	Tahoe	Body	Assist Step Controller																																																								
C	2010	Tahoe	Body	Body Control Module																																																								
C	2010	Tahoe	Body	Body Control Module (aux.)																																																								
C	2010	Tahoe	Body	Digital Radio Receiver																																																								
C	2010	Tahoe	Body	Driver Door Switch																																																								
C	2010	Tahoe	Body	HVAC Control Module Auto																																																								
C	2010	Tahoe	Body	HVAC Control Module Manual																																																								
C	2010	Tahoe	Body	Instrument Panel Cluster																																																								
C	2010	Tahoe	Body	Left Side Object Detection Module																																																								
C	2010	Tahoe	Body	Lift Gate Module																																																								
C	2010	Tahoe	Body	Memory Seat Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2010	Tahoe	Body	Park Assist Module																																																								
C	2010	Tahoe	Body	Passenger Door Switch																																																								
C	2010	Tahoe	Body	Passenger Presence System																																																								
C	2010	Tahoe	Body	Radio																																																								
C	2010	Tahoe	Body	Rear Heated Seat Module																																																								
C	2010	Tahoe	Body	Rear HVAC/RSA																																																								
C	2010	Tahoe	Body	Right Side Object Detection Module																																																								
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																									V	V																														
C	2010	Tahoe	Body	Theft Deterrent Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
C	2010	Tahoe Hybrid	Body	Body Control Module																																																								
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																																								
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																																								
C	2010	Tahoe Hybrid	Body	HVAC Control Module																																												V														
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																																								
C	2010	Tahoe Hybrid	Body	Park Assist Module																																																								
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																								
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																																								
C	2010	Tahoe Hybrid	Body	Radio																																																								
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																									V	V																														
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2011	Avalanche	Chassis	Electronic Brake Control Module																																																								
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																								
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2011	Avalanche	Body	Amplifier (Bose)																																																									
C	2011	Avalanche	Body	Assist Step Controller																																																										
C	2011	Avalanche	Body	Body Control Module																																																										
C	2011	Avalanche	Body	Body Control Module (aux.)																																																										
C	2011	Avalanche	Body	Digital Radio Receiver																																																										
C	2011	Avalanche	Body	Driver Door Switch																																																										
C	2011	Avalanche	Body	HVAC Control Module Auto																																												V														
C	2011	Avalanche	Body	HVAC Control Module Manual																																												V														
C	2011	Avalanche	Body	Instrument Panel Cluster																																																										
C	2011	Avalanche	Body	Memory Seat Module																																																										
C	2011	Avalanche	Body	Park Assist Module																																																										
C	2011	Avalanche	Body	Passenger Door Switch																																																										
C	2011	Avalanche	Body	Passenger Presence System																																																										
C	2011	Avalanche	Body	Radio																																																										
C	2011	Avalanche	Body	Rear Heated Seat Module																																																										
C	2011	Avalanche	Body	Rear HVAC/RSA																																																										
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																									V	V																																
C	2011	Avalanche	Body	Theft Deterrent Module																																																										
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																				V																																					
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2011	Captiva	Chassis	Electronic Brake Control Module					V																																																					
C	2011	Captiva	Chassis	Parking Brake Control Module																																																										
C	2011	Captiva	Body	Body Control Module						V	V	V					V					V	V																									V														
C	2011	Captiva	Body	Auxiliary Body Control Module																																																										
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																												
C	2011	Captiva	Body	Instrument Cluster																																																										
C	2011	Captiva	Body	Headlamp Control Module																																																										
C	2011	Captiva	Body	HVAC Control Module																																																										
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																										
C	2011	Captiva	Body	Parking Assist Control Module																																																										
C	2011	Captiva	Body	Theft Deterrent Module										V																																															
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																								
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																								
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																								
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Cheyenne	Body	Amplifier (Bose)																																																								
C	2011	Cheyenne	Body	Body Control Module																																																								
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																								
C	2011	Cheyenne	Body	Digital Radio Receiver																																																								
C	2011	Cheyenne	Body	Driver Door Switch																																																								
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																								
C	2011	Cheyenne	Body	Park Assist Module																																																								
C	2011	Cheyenne	Body	Passenger Door Switch																																																								
C	2011	Cheyenne	Body	Passenger Presence System																																																								
C	2011	Cheyenne	Body	Rear Heated Seat Module																																																								
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																								
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																									V	V																														
C	2011	Cheyenne	Body	Theft Deterrent Module																																																								
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																								
C	2011	Suburban	Chassis	Electronic Suspension Control																																																								
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Suburban	Body	Amplifier (Bose)																																																								
C	2011	Suburban	Body	Assist Step Controller																																																								
C	2011	Suburban	Body	Body Control Module																																																								
C	2011	Suburban	Body	Body Control Module (aux.)																																																								
C	2011	Suburban	Body	Digital Radio Receiver																																																								
C	2011	Suburban	Body	Driver Door Switch																																																								
C	2011	Suburban	Body	HVAC Control Module Auto																																												V													
C	2011	Suburban	Body	HVAC Control Module Manual																																												V													
C	2011	Suburban	Body	Instrument Panel Cluster																																																								
C	2011	Suburban	Body	Left Side Object Detection Module																																																								
C	2011	Suburban	Body	Lift Gate Module																																																								
C	2011	Suburban	Body	Memory Seat Module																																																								
C	2011	Suburban	Body	Park Assist Module																																																								
C	2011	Suburban	Body	Passenger Door Switch																																																								
C	2011	Suburban	Body	Passenger Presence System																																																								
C	2011	Suburban	Body	Radio																																																								
C	2011	Suburban	Body	Rear Heated Seat Module																																																								
C	2011	Suburban	Body	Rear HVAC/RSA																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2011	Suburban	Body	Right Side Object Detection Module																																																												
C	2011	Suburban	Body	Supplemental Inflatable Restraint																									V	V																																		
C	2011	Suburban	Body	Theft Deterrent Module																																																												
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																												
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2011	Silverado	Chassis	Electronic Suspension Control																																																												
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2011	Silverado	Body	Amplifier (Bose)																																																												
C	2011	Silverado	Body	Body Control Module																																																											
C	2011	Silverado	Body	Body Control Module (aux.)																																																											
C	2011	Silverado	Body	Digital Radio Receiver																																																											
C	2011	Silverado	Body	Driver Door Switch																																																											
C	2011	Silverado	Body	HVAC Control Module Auto																																												V																
C	2011	Silverado	Body	HVAC Control Module Manual																																												V																
C	2011	Silverado	Body	Instrument Panel Cluster																																																											
C	2011	Silverado	Body	Memory Seat Module																																																											
C	2011	Silverado	Body	Park Assist Module																																																											
C	2011	Silverado	Body	Passenger Door Switch																																																											
C	2011	Silverado	Body	Passenger Presence System																																																											
C	2011	Silverado	Body	Radio																																																											
C	2011	Silverado	Body	Rear Heated Seat Module																																																											
C	2011	Silverado	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2011	Silverado	Body	Supplemental Inflatable Restraint																									V	V																														
C	2011	Silverado	Body	Theft Deterrent Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																								
C	2011	Silverado Hybrid	Body	Body Control Module																																																								
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																								
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																								
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																								
C	2011	Silverado Hybrid	Body	HVAC Control Module																																												V													
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
C	2011	Silverado Hybrid	Body	Park Assist Module																																																								
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																								
C	2011	Silverado Hybrid	Body	Passenger Presence System																																																								
C	2011	Silverado Hybrid	Body	Radio																																																								
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																									V	V																														
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																								
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2011	Tahoe	Chassis	Electronic Brake Control Module																																																								
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																								
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Tahoe	Body	Amplifier (Bose)																																																								
C	2011	Tahoe	Body	Assist Step Controller																																																								
C	2011	Tahoe	Body	Body Control Module																																																								
C	2011	Tahoe	Body	Body Control Module (aux.)																																																								
C	2011	Tahoe	Body	Digital Radio Receiver																																																								
C	2011	Tahoe	Body	Driver Door Switch																																																								
C	2011	Tahoe	Body	HVAC Control Module Auto																																												V													
C	2011	Tahoe	Body	HVAC Control Module Manual																																												V													
C	2011	Tahoe	Body	Instrument Panel Cluster																																																								
C	2011	Tahoe	Body	Left Side Object Detection Module																																																								
C	2011	Tahoe	Body	Lift Gate Module																																																								
C	2011	Tahoe	Body	Memory Seat Module																																																								
C	2011	Tahoe	Body	Park Assist Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2011	Tahoe	Body	Passenger Door Switch																																																									
C	2011	Tahoe	Body	Passenger Presence System																																																										
C	2011	Tahoe	Body	Radio																																																										
C	2011	Tahoe	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe	Body	Right Side Object Detection Module																																																										
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																									V	V																																
C	2011	Tahoe	Body	Theft Deterrent Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Tahoe Hybrid	Body	Body Control Module																																																										
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2011	Tahoe Hybrid	Body	HVAC Control Module																																												V															
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2011	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2011	Tahoe Hybrid	Body	Radio																																																										
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2012	Avalanche	Body	Amplifier (Bose)																																																									
C	2012	Avalanche	Body	Assist Step Controller																																																									
C	2012	Avalanche	Body	Body Control Module																																																									
C	2012	Avalanche	Body	Body Control Module (aux.)																																																									
C	2012	Avalanche	Body	Digital Radio Receiver																																																									
C	2012	Avalanche	Body	Driver Door Switch																																																									
C	2012	Avalanche	Body	HVAC Control Module Auto																																												V													
C	2012	Avalanche	Body	HVAC Control Module Manual																																												V													
C	2012	Avalanche	Body	Instrument Panel Cluster																																																									
C	2012	Avalanche	Body	Memory Seat Module																																																									
C	2012	Avalanche	Body	Navigation Radio																																																									
C	2012	Avalanche	Body	Park Assist Module																																																									
C	2012	Avalanche	Body	Passenger Door Switch																																																									
C	2012	Avalanche	Body	Passenger Presence System																																																									
C	2012	Avalanche	Body	Radio																																																									
C	2012	Avalanche	Body	Rear Heated Seat Module																																																									
C	2012	Avalanche	Body	Rear HVAC/RSA																																																									
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																									V	V																															
C	2012	Avalanche	Body	Theft Deterrent Module																																																									
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																									
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																									
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																				V																																					
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																									
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																									
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																									
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																					
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																									
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																									
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																				V																																					
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																									
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																									
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																					
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																									
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																									
C	2012	Captiva	Chassis	Electronic Brake Control Module					V																																																				
C	2012	Captiva	Chassis	Parking Brake Control Module																																																									
C	2012	Captiva	Body	Body Control Module						V	V	V					V					V	V																									V													
C	2012	Captiva	Body	Auxiliary Body Control Module																																																									
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
C	2012	Captiva	Body	Instrument Cluster																																																									
C	2012	Captiva	Body	Headlamp Control Module																																																									
C	2012	Captiva	Body	HVAC Control Module																																																									
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																									
C	2012	Captiva	Body	Parking Assist Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2012	Captiva	Body	Theft Deterrent Module										V																																																	
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																												
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
C	2012	Cheyenne	Body	Amplifier (Bose)																																																												
C	2012	Cheyenne	Body	Body Control Module																																																												
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																												
C	2012	Cheyenne	Body	Digital Radio Receiver																																																												
C	2012	Cheyenne	Body	Driver Door Switch																																																												
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																												
C	2012	Cheyenne	Body	Park Assist Module																																																												
C	2012	Cheyenne	Body	Passenger Door Switch																																																												
C	2012	Cheyenne	Body	Passenger Presence System																																																												
C	2012	Cheyenne	Body	Rear Heated Seat Module																																																												
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																												
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																									V	V																																		
C	2012	Cheyenne	Body	Theft Deterrent Module																																																												
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																												
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																												
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2012	Suburban	Chassis	Electronic Suspension Control																																																												
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
C	2012	Suburban	Body	Amplifier (Bose)																																																												
C	2012	Suburban	Body	Assist Step Controller																																																												
C	2012	Suburban	Body	Body Control Module																																																												
C	2012	Suburban	Body	Body Control Module (aux.)																																																												
C	2012	Suburban	Body	Digital Radio Receiver																																																												
C	2012	Suburban	Body	Driver Door Switch																																																												
C	2012	Suburban	Body	HVAC Control Module Auto																																												V																
C	2012	Suburban	Body	HVAC Control Module Manual																																												V																
C	2012	Suburban	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2012	Suburban	Body	Left Side Object Detection Module																																																												
C	2012	Suburban	Body	Lift Gate Module																																																													
C	2012	Suburban	Body	Memory Seat Module																																																													
C	2012	Suburban	Body	Navigation Radio																																																													
C	2012	Suburban	Body	Park Assist Module																																																													
C	2012	Suburban	Body	Passenger Door Switch																																																													
C	2012	Suburban	Body	Passenger Presence System																																																													
C	2012	Suburban	Body	Radio																																																													
C	2012	Suburban	Body	Rear Heated Seat Module																																																													
C	2012	Suburban	Body	Rear HVAC/RSA																																																													
C	2012	Suburban	Body	Right Side Object Detection Module																																																													
C	2012	Suburban	Body	Supplemental Inflatable Restraint																									V	V																																			
C	2012	Suburban	Body	Theft Deterrent Module																																																													
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																													
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																													
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																													
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																													
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																													
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																													
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																													
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																													
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																													
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																													
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																													
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																													
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																													
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																													
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													
C	2012	Silverado	Chassis	Electronic Suspension Control																																																													
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																													
C	2012	Silverado	Body	Amplifier (Bose)																																																													
C	2012	Silverado	Body	Body Control Module																																																													
C	2012	Silverado	Body	Body Control Module (aux.)																																																													
C	2012	Silverado	Body	Digital Radio Receiver																																																													
C	2012	Silverado	Body	Driver Door Switch																																																													
C	2012	Silverado	Body	HVAC Control Module Auto																																													V																	

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2012	Silverado	Body	HVAC Control Module Manual																																												V											
C	2012	Silverado	Body	Instrument Panel Cluster																																																						
C	2012	Silverado	Body	Memory Seat Module																																																						
C	2012	Silverado	Body	Navigation Radio																																																						
C	2012	Silverado	Body	Park Assist Module																																																						
C	2012	Silverado	Body	Passenger Door Switch																																																						
C	2012	Silverado	Body	Passenger Presence System																																																						
C	2012	Silverado	Body	Radio																																																						
C	2012	Silverado	Body	Rear Heated Seat Module																																																						
C	2012	Silverado	Body	Rear HVAC/RSA																																																						
C	2012	Silverado	Body	Supplemental Inflatable Restraint																									V	V																													
C	2012	Silverado	Body	Theft Deterrent Module																																																						
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																						
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																						
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																						
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																						
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																						
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																						
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																						
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																						
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																						
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																						
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																						
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																						
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																						
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																						
C	2012	Silverado Hybrid	Body	Body Control Module																																																						
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																						
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																						
C	2012	Silverado Hybrid	Body	Driver Door Switch																																																						
C	2012	Silverado Hybrid	Body	Heated Seat Module																																																						
C	2012	Silverado Hybrid	Body	HVAC Control Module																																												V											
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																						
C	2012	Silverado Hybrid	Body	Navigation Radio																																																						
C	2012	Silverado Hybrid	Body	Park Assist Module																																																						
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																																						
C	2012	Silverado Hybrid	Body	Passenger Presence System																																																						
C	2012	Silverado Hybrid	Body	Radio																																																						
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																						
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																						
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																						
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																									V	V																													
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																						
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																						
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																						
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
C	2012	Tahoe	Chassis	Electronic Brake Control Module																																																						
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																						
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																						
C	2012	Tahoe	Body	Amplifier (Bose)																																																						
C	2012	Tahoe	Body	Assist Step Controller																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2012	Tahoe	Body	Body Control Module																																																												
C	2012	Tahoe	Body	Body Control Module (aux.)																																																												
C	2012	Tahoe	Body	Digital Radio Receiver																																																												
C	2012	Tahoe	Body	Driver Door Switch																																																												
C	2012	Tahoe	Body	HVAC Control Module Auto																																												V															
C	2012	Tahoe	Body	HVAC Control Module Manual																																												V															
C	2012	Tahoe	Body	Instrument Panel Cluster																																																												
C	2012	Tahoe	Body	Left Side Object Detection Module																																																												
C	2012	Tahoe	Body	Lift Gate Module																																																												
C	2012	Tahoe	Body	Memory Seat Module																																																												
C	2012	Tahoe	Body	Navigation Radio																																																												
C	2012	Tahoe	Body	Park Assist Module																																																												
C	2012	Tahoe	Body	Passenger Door Switch																																																												
C	2012	Tahoe	Body	Passenger Presence System																																																												
C	2012	Tahoe	Body	Radio																																																											
C	2012	Tahoe	Body	Rear Heated Seat Module																																																												
C	2012	Tahoe	Body	Rear HVAC/RSA																																																												
C	2012	Tahoe	Body	Right Side Object Detection Module																																																												
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																									V	V																																		
C	2012	Tahoe	Body	Theft Deterrent Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2012	Tahoe Hybrid	Body	Body Control Module																																																												
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																																												
C	2012	Tahoe Hybrid	Body	HVAC Control Module																																												V															
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
C	2012	Tahoe Hybrid	Body	Lift Gate Module																																																												
C	2012	Tahoe Hybrid	Body	Navigation Radio																																																												
C	2012	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																												
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																																												
C	2012	Tahoe Hybrid	Body	Radio																																																												
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																	
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2013	Avalanche	Chassis	Electronic Brake Control Module																																																											
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																											
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Avalanche	Body	Amplifier (Bose)																																																											
C	2013	Avalanche	Body	Assist Step Controller																																																											
C	2013	Avalanche	Body	Body Control Module																																																											
C	2013	Avalanche	Body	Body Control Module (aux.)																																																											
C	2013	Avalanche	Body	Digital Radio Receiver																																																											
C	2013	Avalanche	Body	Driver Door Switch																																																											
C	2013	Avalanche	Body	HVAC Control Module Auto																																												V															
C	2013	Avalanche	Body	HVAC Control Module Manual																																												V															
C	2013	Avalanche	Body	Instrument Panel Cluster																																																											
C	2013	Avalanche	Body	Memory Seat Module																																																											
C	2013	Avalanche	Body	Navigation Radio																																																											
C	2013	Avalanche	Body	Park Assist Module																																																											
C	2013	Avalanche	Body	Passenger Door Switch																																																											
C	2013	Avalanche	Body	Passenger Presence System																																																											
C	2013	Avalanche	Body	Radio																																																											
C	2013	Avalanche	Body	Rear Heated Seat Module																																																											
C	2013	Avalanche	Body	Rear HVAC/RSA																																																											
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																									V	V																																	
C	2013	Avalanche	Body	Theft Deterrent Module																																																											
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																											
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																											
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																				V																																							
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																											
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																											
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																							
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																											
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																											
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																							
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
C	2013	Captiva	Chassis	Electronic Brake Control Module					V																																																						
C	2013	Captiva	Chassis	Parking Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto						V	V	V						V					V	V																																				
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual						V	V	V						V					V	V																								V											
C	2013	Captiva	Body	Auxiliary Body Control Module																																																							
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																									
C	2013	Captiva	Body	Instrument Cluster																																																						
C	2013	Captiva	Body	Headlamp Control Module																																																						
C	2013	Captiva	Body	HVAC Control Module																																																						
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																						
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)										V			V																																									
C	2013	Captiva	Body	Theft Deterrent Module										V																																												
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																						
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																						
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																						
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																						
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																						
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																						
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																						
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																						
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																						
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																						
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																						
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																						
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																						
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																						
C	2013	Cheyenne	Body	Amplifier (Bose)																																																						
C	2013	Cheyenne	Body	Body Control Module																																																					
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																					
C	2013	Cheyenne	Body	Digital Radio Receiver																																																					
C	2013	Cheyenne	Body	Driver Door Switch																																																					
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																					
C	2013	Cheyenne	Body	Park Assist Module																																																					
C	2013	Cheyenne	Body	Passenger Door Switch																																																					
C	2013	Cheyenne	Body	Passenger Presence System																																																					
C	2013	Cheyenne	Body	Rear Heated Seat Module																																																					
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																					
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																									V	V																												
C	2013	Cheyenne	Body	Theft Deterrent Module																																																					
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																					
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																					
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																					
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																					
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																					
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																					
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																					
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																					
C	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																					
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																					
C	2013	Suburban	Chassis	Electronic Suspension Control																																																					
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Suburban	Body	Amplifier (Bose)																																																										
C	2013	Suburban	Body	Assist Step Controller																																																										
C	2013	Suburban	Body	Body Control Module																																																										
C	2013	Suburban	Body	Body Control Module (aux.)																																																										
C	2013	Suburban	Body	Digital Radio Receiver																																																										
C	2013	Suburban	Body	Driver Door Switch																																																										
C	2013	Suburban	Body	HVAC Control Module Auto																																													V													
C	2013	Suburban	Body	HVAC Control Module Manual																																													V													
C	2013	Suburban	Body	Instrument Panel Cluster																																																										
C	2013	Suburban	Body	Left Side Object Detection Module																																																										
C	2013	Suburban	Body	Lift Gate Module																																																										
C	2013	Suburban	Body	Memory Seat Module																																																										
C	2013	Suburban	Body	Navigation Radio																																																										
C	2013	Suburban	Body	Park Assist Module																																																										
C	2013	Suburban	Body	Passenger Door Switch																																																										
C	2013	Suburban	Body	Passenger Presence System																																																										
C	2013	Suburban	Body	Radio																																																										
C	2013	Suburban	Body	Rear Heated Seat Module																																																										
C	2013	Suburban	Body	Rear HVAC/RSA																																																										
C	2013	Suburban	Body	Right Side Object Detection Module																																																										
C	2013	Suburban	Body	Supplemental Inflatable Restraint																									V	V																																
C	2013	Suburban	Body	Theft Deterrent Module																																																										
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																										
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
C	2013	Silverado	Chassis	Electronic Suspension Control																																																										
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2013	Silverado	Body	Amplifier (Bose)																																																										
C	2013	Silverado	Body	Body Control Module																																																										
C	2013	Silverado	Body	Body Control Module (aux.)																																																										
C	2013	Silverado	Body	Digital Radio Receiver																																																										
C	2013	Silverado	Body	Driver Door Switch																																																										
C	2013	Silverado	Body	HVAC Control Module Auto																																												V														
C	2013	Silverado	Body	HVAC Control Module Manual																																												V														
C	2013	Silverado	Body	Instrument Panel Cluster																																																										
C	2013	Silverado	Body	Memory Seat Module																																																										
C	2013	Silverado	Body	Navigation Radio																																																										
C	2013	Silverado	Body	Park Assist Module																																																										
C	2013	Silverado	Body	Passenger Door Switch																																																										
C	2013	Silverado	Body	Passenger Presence System																																																										
C	2013	Silverado	Body	Radio																																																										
C	2013	Silverado	Body	Rear Heated Seat Module																																																										
C	2013	Silverado	Body	Rear HVAC/RSA																																																										
C	2013	Silverado	Body	Supplemental Inflatable Restraint																									V	V																																
C	2013	Silverado	Body	Theft Deterrent Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2013	Silverado Hybrid	Body	Body Control Module																																																										
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2013	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2013	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2013	Silverado Hybrid	Body	HVAC Control Module																																												V														
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2013	Silverado Hybrid	Body	Navigation Radio																																																										
C	2013	Silverado Hybrid	Body	Park Assist Module																																																										
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2013	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2013	Silverado Hybrid	Body	Radio																																																										
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																									V	V																														
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																								
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2013	Tahoe	Chassis	Electronic Brake Control Module																																																								
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																								
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Tahoe	Body	Amplifier (Bose)																																																								
C	2013	Tahoe	Body	Assist Step Controller																																																								
C	2013	Tahoe	Body	Body Control Module																																																								
C	2013	Tahoe	Body	Body Control Module (aux.)																																																								
C	2013	Tahoe	Body	Digital Radio Receiver																																																								
C	2013	Tahoe	Body	Driver Door Switch																																																								
C	2013	Tahoe	Body	HVAC Control Module Auto																																													V											
C	2013	Tahoe	Body	HVAC Control Module Manual																																													V											
C	2013	Tahoe	Body	Instrument Panel Cluster																																																								
C	2013	Tahoe	Body	Left Side Object Detection Module																																																								
C	2013	Tahoe	Body	Lift Gate Module																																																								
C	2013	Tahoe	Body	Memory Seat Module																																																								
C	2013	Tahoe	Body	Navigation Radio																																																								
C	2013	Tahoe	Body	Park Assist Module																																																								
C	2013	Tahoe	Body	Passenger Door Switch																																																								
C	2013	Tahoe	Body	Passenger Presence System																																																								
C	2013	Tahoe	Body	Radio																																																								
C	2013	Tahoe	Body	Rear Heated Seat Module																																																								
C	2013	Tahoe	Body	Rear HVAC/RSA																																																								
C	2013	Tahoe	Body	Right Side Object Detection Module																																																								
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																									V	V																														
C	2013	Tahoe	Body	Theft Deterrent Module																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
C	2013	Tahoe Hybrid	Body	Body Control Module																																																								
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																																									
C	2013	Tahoe Hybrid	Body	HVAC Control Module																																													V											
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
C	2013	Tahoe Hybrid	Body	Lift Gate Module																																																								
C	2013	Tahoe Hybrid	Body	Navigation Radio																																																								
C	2013	Tahoe Hybrid	Body	Park Assist Module																																																								
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																								
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																																								
C	2013	Tahoe Hybrid	Body	Radio																																																								
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																									V	V																														
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																				V																																				
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																				
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																								
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module					V																																																			
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																								
C	2014	Captiva (3GN)	Body	Body Control Module						V	V	V						V				V	V	V																									V										
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
C	2014	Captiva (3GN)	Body	Passenger Presence Module																										V																														
C	2014	Captiva (3GN)	Body	Instrument Cluster																																																								
C	2014	Captiva (3GN)	Body	Radio																																																								
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																								
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																								
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																				
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																					
C	2014	Captiva (3GN)	Body	HVAC Control Module																																										V	V		V	V									
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																				V	V																		
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																								
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																								
C	2014	Captiva (3GN)	Body	Theft Deterrent Module										V																																														
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																								
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																				V																																				
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																				
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																								
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																				
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																									
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																								
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module					V																																																			
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																								
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto						V	V	V						V					V	V																																				
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual						V	V	V						V					V	V																								V												
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																								
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
C	2014	Captiva (Other)	Body	Instrument Cluster																																																								
C	2014	Captiva (Other)	Body	Headlamp Control Module																																																								
C	2014	Captiva (Other)	Body	HVAC Control Module																																																								
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																								
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)										V			V																																										
C	2014	Captiva (Other)	Body	Theft Deterrent Module										V																																														
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																				
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																				
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																		
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control						V																																																		
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2014	Cheyenne	Chassis	Electronic Brake Control Module					V																																																			
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																								
C	2014	Cheyenne	Chassis	Power Steering Control Module																																																								
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
C	2014	Cheyenne	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V	V		V	V																										V						
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
C	2014	Cheyenne	Body	Passenger Presence Module																																V																								
C	2014	Cheyenne	Body	Instrument Cluster																																	V																							
C	2014	Cheyenne	Body	Radio Control																																																								
C	2014	Cheyenne	Body	HVAC Control																																																								
C	2014	Cheyenne	Body	Radio																																																								
C	2014	Cheyenne	Body	Amplifier																																																								
C	2014	Cheyenne	Body	Media Disc Player																																																								
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																								
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																	V	V	V	V																				
C	2014	Cheyenne	Body	HVAC Control Module																														V														V	V	V		V								
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																									V	V														
C	2014	Cheyenne	Body	Parking Assist Control Module																																V																								
C	2014	Cheyenne	Body	Frontview Camera Module																																																								
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																				
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																				
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																							
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																							
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																							
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																							
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control						V																																																
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																						
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																						
C	2014	Silverado	Chassis	Electronic Brake Control Module					V																																																	
C	2014	Silverado	Chassis	Parking Brake Control Module																																																						
C	2014	Silverado	Chassis	Power Steering Control Module																																																						
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
C	2014	Silverado	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V	V		V	V																							V						
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
C	2014	Silverado	Body	Passenger Presence Module																																V																						
C	2014	Silverado	Body	Instrument Cluster																																	V																				
C	2014	Silverado	Body	Radio Control																																																					
C	2014	Silverado	Body	HVAC Control																																																					
C	2014	Silverado	Body	Radio																																																					
C	2014	Silverado	Body	Amplifier																																																					
C	2014	Silverado	Body	Media Disc Player																																																					
C	2014	Silverado	Body	Human Machine Interface Control Module																																																					
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																	
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																		
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V	V		V						
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																														V												V	V	V		V						
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																														V												V	V	V		V						
C	2014	Silverado	Body	Parking Assist Control Module																																V																					
C	2014	Silverado	Body	Frontview Camera Module																																																					
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																						
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																			
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																						
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																			
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																						
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																						
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																						
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																						
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																						
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																						
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																						
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																						
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																						
C	2014	Silverado HD	Chassis	Suspension Control Module																																																						
C	2014	Silverado HD	Body	Body Control Module						V	V	V						V				V	V	V																																			
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																								
C	2014	Silverado HD	Body	Passenger Presence Module																										V																												
C	2014	Silverado HD	Body	Instrument Cluster																																																					
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																					
C	2014	Silverado HD	Body	Base Radio																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2014	Silverado HD	Body	Navigation Radio																																																									
C	2014	Silverado HD	Body	Uplevel Radio																																																									
C	2014	Silverado HD	Body	Amplifier																																																								
C	2014	Silverado HD	Body	Rear Audio Control Module																																																								
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																								
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																								
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																			
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																				
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																									V	V			V									
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																									V	V			V									
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																									V	V			V									
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																									V	V			V									
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																	V																																							
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																								
C	2014	Silverado HD	Body	Seat Memory Control Module																																					V	V																		
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																								
C	2014	Silverado HD	Body	Parking Assist Control Module																																																								
C	2014	Silverado HD	Body	Theft Deterrent Module										V																																														
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																								
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																								
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump						V																																																	
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																								
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																								
C	2014	Suburban	Chassis	Parking Brake Control Module																																																								
C	2014	Suburban	Chassis	Suspension Control Module																																																								
C	2014	Suburban	Body	Body Control Module						V	V	V						V				V	V	V																																				
C	2014	Suburban	Body	Auxiliary Body Control Module																																																								
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
C	2014	Suburban	Body	Passenger Presence Module																										V																														
C	2014	Suburban	Body	Instrument Cluster																																																								
C	2014	Suburban	Body	Base Radio																																																								
C	2014	Suburban	Body	Navigation Radio																																																								
C	2014	Suburban	Body	Uplevel Radio																																																								
C	2014	Suburban	Body	Amplifier																																																								
C	2014	Suburban	Body	Rear Audio Control Module																																																								
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																								
C	2014	Suburban	Body	Personal Audio Link Control Module																																																								
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																			
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																				
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																									V	V			V									
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																									V	V			V									
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																	V																																							
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																								
C	2014	Suburban	Body	Liftgate Control Module																																																								
C	2014	Suburban	Body	Seat Memory Control Module																																					V	V																		
C	2014	Suburban	Body	Rear Seat Heating Control Module																																							V	V															

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2014	Suburban	Body	Assist Step Control Module																																																								
C	2014	Suburban	Body	Right Side Object Detection Control Module																																										V	V													
C	2014	Suburban	Body	Left Side Object Detection Control Module																																										V	V													
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																								
C	2014	Suburban	Body	Parking Assist Control Module																																																								
C	2014	Suburban	Body	Theft Deterrent Module										V																																														
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump						V																																																		
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																								
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																								
C	2014	Tahoe	Chassis	Suspension Control Module																																																								
C	2014	Tahoe	Body	Body Control Module						V	V	V						V				V	V	V																																				
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																								
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
C	2014	Tahoe	Body	Passenger Presence Module																										V																														
C	2014	Tahoe	Body	Instrument Cluster																																																								
C	2014	Tahoe	Body	Base Radio																																																								
C	2014	Tahoe	Body	Navigation Radio																																																								
C	2014	Tahoe	Body	Uplevel Radio																																																								
C	2014	Tahoe	Body	Amplifier																																																								
C	2014	Tahoe	Body	Rear Audio Control Module																																																								
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																								
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																								
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																												V	V			V									
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																												V	V			V									
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																	V																																							
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																								
C	2014	Tahoe	Body	Liftgate Control Module																																																								
C	2014	Tahoe	Body	Seat Memory Control Module																																				V	V																			
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																							V	V																
C	2014	Tahoe	Body	Assist Step Control Module																																																								
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																										V	V													
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																										V	V													
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																								
C	2014	Tahoe	Body	Parking Assist Control Module																																																								
C	2014	Tahoe	Body	Theft Deterrent Module										V																																														
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																				V																																				
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																				
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																								
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module					V																																																			
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2015	Captiva (3GN)	Body	Body Control Module						V	V	V						V				V	V	V																								V											
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																									
C	2015	Captiva (3GN)	Body	Passenger Presence Module																										V																													
C	2015	Captiva (3GN)	Body	Instrument Cluster																																																						
C	2015	Captiva (3GN)	Body	Radio																																																						
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																						
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																						
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																V	V	V																					
C	2015	Captiva (3GN)	Body	HVAC Control Module																																									V	V		V	V									
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																				V	V																	
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																						
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																						
C	2015	Captiva (3GN)	Body	Theft Deterrent Module										V																																												
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																						
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																						
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																						
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																						
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																						
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																						
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																			
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																						
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																						
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																			
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																						
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																						
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																						
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																						
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module					V																																																	
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																						
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto						V	V	V						V					V	V																																			
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual						V	V	V						V					V	V																							V											
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																						
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																									
C	2015	Captiva (Other)	Body	Instrument Cluster																																																						
C	2015	Captiva (Other)	Body	Headlamp Control Module																																																						
C	2015	Captiva (Other)	Body	HVAC Control Module																																																						
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																						
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)										V			V																																									
C	2015	Captiva (Other)	Body	Theft Deterrent Module										V																																												
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																			
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																			
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																						
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																			
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																						
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																			
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																						
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																						
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																			
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																						
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control						V																																																

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																								
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																								
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2015	Cheyenne	Chassis	Electronic Brake Control Module					V																																																			
C	2015	Cheyenne	Chassis	Power Steering Control Module																																																								
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
C	2015	Cheyenne	Chassis	Suspension Control Module																																																								
C	2015	Cheyenne	Body	Body Control Module						V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V								
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
C	2015	Cheyenne	Body	Passenger Presence Module																				V																																				
C	2015	Cheyenne	Body	Instrument Cluster																																V																								
C	2015	Cheyenne	Body	Radio Controls																																																								
C	2015	Cheyenne	Body	HVAC Controls																																																								
C	2015	Cheyenne	Body	Radio																																																								
C	2015	Cheyenne	Body	Amplifier																																																								
C	2015	Cheyenne	Body	Media Disc Player																																																								
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																								
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																V	V	V	V																					
C	2015	Cheyenne	Body	HVAC Control Module																														V													V	V	V		V									
C	2015	Cheyenne	Body	Parking Assist Control Module																															V																									
C	2015	Cheyenne	Body	Frontview Camera Module																																																								
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																				
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																				
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																		
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control						V																																																		
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																								
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																								
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2015	Silverado	Chassis	Electronic Brake Control Module					V																																																			
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																								
C	2015	Silverado	Chassis	Power Steering Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
C	2015	Silverado	Chassis	Suspension Control Module																																																								
C	2015	Silverado	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V						
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
C	2015	Silverado	Body	Passenger Presence Module																																V																								
C	2015	Silverado	Body	Instrument Cluster																																	V																						
C	2015	Silverado	Body	Radio Controls																																																							
C	2015	Silverado	Body	HVAC Controls																																																							
C	2015	Silverado	Body	Radio																																																							
C	2015	Silverado	Body	Amplifier																																																							
C	2015	Silverado	Body	Media Disc Player																																																							
C	2015	Silverado	Body	Human Machine Interface Control Module																																																							
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																	V	V	V	V																				
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V	V		V								
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																														V												V	V	V		V								
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																														V												V	V	V		V								
C	2015	Silverado	Body	Parking Assist Control Module																																V																								
C	2015	Silverado	Body	Frontview Camera Module																																																							
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																							
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																							
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																	
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control						V																																																	
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																							
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																							
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																							
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																							
C	2015	Suburban	Chassis	Electronic Brake Control Module					V																																																		
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																							
C	2015	Suburban	Chassis	Parking Brake Control Module																																																							
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																							
C	2015	Suburban	Chassis	Power Steering Control Module																																																							
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
C	2015	Suburban	Chassis	Suspension Control Module																																																							
C	2015	Suburban	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																									V						
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
C	2015	Suburban	Body	Passenger Presence Module																																V																								
C	2015	Suburban	Body	Instrument Cluster																																	V																						
C	2015	Suburban	Body	Radio Controls																																																						
C	2015	Suburban	Body	HVAC Controls																																																						
C	2015	Suburban	Body	Radio																																																						
C	2015	Suburban	Body	Amplifier																																																						
C	2015	Suburban	Body	Media Disc Player																																																						
C	2015	Suburban	Body	Human Machine Interface Control Module																																																						
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																	V	V	V	V																			
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																			
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
C	2015	Suburban	Body	HVAC Control Module																														V												V	V	V		V								
C	2015	Suburban	Body	Liftgate Control Module																																																						
C	2015	Suburban	Body	Keyless Entry Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2015	Suburban	Body	Assist Step Control Module																																																								
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																									
C	2015	Suburban	Body	Parking Assist Control Module																																V																									
C	2015	Suburban	Body	Frontview Camera Module																																																								
C	2015	Suburban	Body	Steering Column Lock Control Module																																																								
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																	
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control						V																																																	
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																								
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																								
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																								
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																								
C	2015	Tahoe	Chassis	Electronic Brake Control Module					V																																																			
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																								
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																								
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																								
C	2015	Tahoe	Chassis	Power Steering Control Module																																																								
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
C	2015	Tahoe	Chassis	Suspension Control Module																																																								
C	2015	Tahoe	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V							
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
C	2015	Tahoe	Body	Passenger Presence Module																																V																								
C	2015	Tahoe	Body	Instrument Cluster																																V																								
C	2015	Tahoe	Body	Radio Controls																																																							
C	2015	Tahoe	Body	HVAC Controls																																																							
C	2015	Tahoe	Body	Radio																																																							
C	2015	Tahoe	Body	Amplifier																																																							
C	2015	Tahoe	Body	Media Disc Player																																																							
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																							
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																	V	V	V	V																			
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																			
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
C	2015	Tahoe	Body	HVAC Control Module																														V												V	V	V		V							
C	2015	Tahoe	Body	Liftgate Control Module																																																							
C	2015	Tahoe	Body	Keyless Entry Control Module																																																								
C	2015	Tahoe	Body	Assist Step Control Module																																																								
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																								
C	2015	Tahoe	Body	Parking Assist Control Module																																V																								
C	2015	Tahoe	Body	Frontview Camera Module																																																								
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																								
C	2015	Tahoe	Body	Battery Energy Control Module																																																								
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																				V																																				
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																				
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module					V																																																				
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																									
C	2016	Captiva (3GN)	Body	Body Control Module						V	V	V						V				V	V	V																							V												
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																								
C	2016	Captiva (3GN)	Body	Radio																																																								
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																								
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																V	V	V																					
C	2016	Captiva (3GN)	Body	HVAC Control Module																																									V	V		V	V										
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																				V	V																		
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																								
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																								
C	2016	Captiva (3GN)	Body	Theft Deterrent Module										V																																														
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																				V																															V				
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																		V				
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																		V				
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																							
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																							
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																							
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																							
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																							
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																							
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																				
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																							
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																							
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																				
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																							
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																							
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																							
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																							
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module					V																																																		
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																							
C	2016	Captiva (Other)	Chassis	Power Steering Control Module	V	V	V																																																					
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto						V	V	V						V					V	V																																				
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual						V	V	V						V					V	V																								V												
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																							
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
C	2016	Captiva (Other)	Body	Instrument Cluster																																																							
C	2016	Captiva (Other)	Body	Headlamp Control Module																																																							
C	2016	Captiva (Other)	Body	Radio																																																						
C	2016	Captiva (Other)	Body	HVAC Control Module																																																						
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																						
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																						
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																						
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)										V			V																																									
C	2016	Captiva (Other)	Body	Theft Deterrent Module										V																																													
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																			
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																						
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																			
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																						
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Cheyenne	Chassis	Electronic Brake Control Module					V																																																					
C	2016	Cheyenne	Chassis	Power Steering Control Module																																																										
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
C	2016	Cheyenne	Chassis	Suspension Control Module																																																										
C	2016	Cheyenne	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																								V								
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
C	2016	Cheyenne	Body	Passenger Presence Module																																V																										
C	2016	Cheyenne	Body	Instrument Cluster																																	V																								
C	2016	Cheyenne	Body	Radio Controls																																																									
C	2016	Cheyenne	Body	HVAC Controls																																																									
C	2016	Cheyenne	Body	Radio																																																									
C	2016	Cheyenne	Body	Amplifier																																																									
C	2016	Cheyenne	Body	Media Disc Player																																																									
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																									
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																	V	V	V																						
C	2016	Cheyenne	Body	HVAC Control Module																														V														V	V	V		V								
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																									
C	2016	Cheyenne	Body	Parking Assist Control Module																																V																										
C	2016	Cheyenne	Body	Frontview Camera Module																																																									
C	2016	Cheyenne	Body	Frontview Camera Module																																																									
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																					
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																					
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																					
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																				V																																					
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																								V	V
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																					
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																					
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																					
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Silverado	Chassis	Electronic Brake Control Module					V																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2016	Silverado	Chassis	Power Steering Control Module																																																					V				
C	2016	Silverado	Chassis	Power Steering Control Module																																																								
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
C	2016	Silverado	Chassis	Suspension Control Module																																																								
C	2016	Silverado	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																								V						
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
C	2016	Silverado	Body	Passenger Presence Module																																V																								
C	2016	Silverado	Body	Instrument Cluster																																	V																						
C	2016	Silverado	Body	Radio Controls																																																							
C	2016	Silverado	Body	HVAC Controls																																																							
C	2016	Silverado	Body	Radio (IO3)																																																							
C	2016	Silverado	Body	Radio (IOB)																																																							
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																							
C	2016	Silverado	Body	Amplifier																																																							
C	2016	Silverado	Body	Media Disc Player																																																							
C	2016	Silverado	Body	Human Machine Interface Control Module																																																							
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																														V													V	V	V		V							
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																														V													V	V	V		V							
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																														V													V	V	V		V							
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																							
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																							
C	2016	Silverado	Body	Parking Assist Control Module																																V																								
C	2016	Silverado	Body	Frontview Camera Module																																																							
C	2016	Silverado	Body	Frontview Camera Module																																																							
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																							
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																							
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																							
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																							
C	2016	Suburban	Chassis	Electronic Brake Control Module					V																																																		
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																							
C	2016	Suburban	Chassis	Parking Brake Control Module																																																							
C	2016	Suburban	Chassis	Power Steering Control Module																																																							
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
C	2016	Suburban	Chassis	Suspension Control Module																																																							
C	2016	Suburban	Body	Body Control Module						V	V	V		V	V		V	V	V		V	V	V	V	V	V	V	V																								V						
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
C	2016	Suburban	Body	Passenger Presence Module																																V																								
C	2016	Suburban	Body	Instrument Cluster																																	V																						
C	2016	Suburban	Body	Radio Controls																																																							
C	2016	Suburban	Body	HVAC Controls																																																							
C	2016	Suburban	Body	Radio																																																							
C	2016	Suburban	Body	Amplifier																																																							
C	2016	Suburban	Body	Media Disc Player																																																							
C	2016	Suburban	Body	Human Machine Interface Control Module																																																							
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																	V	V	V																				
C	2016	Suburban	Body	HVAC Control Module																														V													V	V	V		V							
C	2016	Suburban	Body	Liftgate Control Module																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																								
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																								
C	2016	Suburban	Body	Keyless Entry Control Module																																																								
C	2016	Suburban	Body	Assist Step Control Module																																																								
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																								
C	2016	Suburban	Body	Parking Assist Control Module																																V																								
C	2016	Suburban	Body	Frontview Camera Module																																																								
C	2016	Suburban	Body	Steering Column Lock Control Module																																																								
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2016	Tahoe	Chassis	Electronic Brake Control Module					V																																																			
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																								
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																								
C	2016	Tahoe	Chassis	Power Steering Control Module																																																								
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
C	2016	Tahoe	Chassis	Suspension Control Module																																																								
C	2016	Tahoe	Body	Body Control Module						V	V	V		V	V		V	V	V		V	V	V	V	V	V	V	V																										V						
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
C	2016	Tahoe	Body	Passenger Presence Module																															V																									
C	2016	Tahoe	Body	Instrument Cluster																																V																								
C	2016	Tahoe	Body	Radio Controls																																																								
C	2016	Tahoe	Body	HVAC Controls																																																								
C	2016	Tahoe	Body	Radio																																																								
C	2016	Tahoe	Body	Amplifier																																																								
C	2016	Tahoe	Body	Media Disc Player																																																								
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																								
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																V	V	V																						
C	2016	Tahoe	Body	HVAC Control Module																														V													V	V	V		V									
C	2016	Tahoe	Body	Liftgate Control Module																																																								
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																								
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																								
C	2016	Tahoe	Body	Keyless Entry Control Module																																																								
C	2016	Tahoe	Body	Assist Step Control Module																																																								
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																								
C	2016	Tahoe	Body	Parking Assist Control Module																																V																								
C	2016	Tahoe	Body	Frontview Camera Module																																																								
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																								
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																								
E	2004	ALL	Chassis	Electronic Brake Control Module																																																								
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
E	2006	ALL	Chassis	Electronic Brake Control Module																																																								
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
E	2007	ALL	Chassis	Electronic Brake Control Module																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																										
G	2004	Express/Savana	Body	Body Control Module																														V																												
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2004	Express/Savana	Body	OnStar																																V																										
G	2004	Express/Savana	Body	Base Radio																																																									
G	2004	Express/Savana	Body	Uplevel Radio																																																										
G	2004	Express/Savana	Body	Remote Function Actuation																																																										
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																														V																												
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																V																										
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2005	Express/Savana	Chassis	VSES																																																									
G	2005	Express/Savana	Body	Body Control Module																														V																												
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2005	Express/Savana	Body	Base Radio																																																									
G	2005	Express/Savana	Body	Uplevel Radio																																																									
G	2005	Express/Savana	Body	Remote Function Actuation																																																									
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																V																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2005	Express Access/Savana Pro	Chassis	VSES																																																									
G	2005	Express Access/Savana Pro	Body	Body Control Module																														V																												
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2005	Express Access/Savana Pro	Body	Base Radio																																																									
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																V																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																								
G	2006	Express/Savana	Chassis	VSES																																																								
G	2006	Express/Savana	Body	Body Control Module																														V																										
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2006	Express/Savana	Body	Passenger Presence System																																																								
G	2006	Express/Savana	Body	Base Radio																																																								
G	2006	Express/Savana	Body	Uplevel Radio																																																								
G	2006	Express/Savana	Body	Remote Function Actuation																																																								
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																V																								
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
G	2006	Express Access/Savana Pro	Chassis	VSES																																																								
G	2006	Express Access/Savana Pro	Body	Body Control Module																														V																										
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2006	Express Access/Savana Pro	Body	Base Radio																																																								
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																								
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																	V																							
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																							
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																							
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																							
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																							
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																							
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																							
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																							
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																							
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																							
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																							
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2007	Express/Savana	Body	Body Control Module																														V																										
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																							
G	2007	Express/Savana	Body	Passenger Presence System																																																							
G	2007	Express/Savana	Body	Base Radio																																																							
G	2007	Express/Savana	Body	Uplevel Radio																																																							
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																							
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																	V																							
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																							
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																							
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2007	Express Access/Savana Pro	Body	Body Control Module																														V																										
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2007	Express Access/Savana Pro	Body	Radio																																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																V																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2008	Express/Savana	Body	Body Control Module																																																								
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2008	Express/Savana	Body	Passenger Presence System																																																								
G	2008	Express/Savana	Body	Radio																																																								
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2008	Express/Savana	Body	Rollover Sensor																																																								
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2008	Express/Savana	Body	Theft Deterrent Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2008	Express Access/Savana Pro	Body	Radio																																																										
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2009	Express/Savana	Body	Body Control Module																																																										
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2009	Express/Savana	Body	Passenger Presence System																																																										
G	2009	Express/Savana	Body	Radio																																																										
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express/Savana	Body	Rollover Sensor																																																										
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2009	Express/Savana	Body	Theft Deterrent Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2009	Express Access/Savana Pro	Body	Radio																																																									
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2010	Express/Savana	Body	Body Control Module																																																									
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2010	Express/Savana	Body	Passenger Presence System																																																									
G	2010	Express/Savana	Body	Radio																																																									
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2010	Express/Savana	Body	Rollover Sensor																																																									
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2010	Express/Savana	Body	Theft Deterrent Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2010	Express Access/Savana Pro	Body	Radio																																																											
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																											
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2011	Express/Savana	Body	Body Control Module																																																											
G	2011	Express/Savana	Body	Digital Radio Receiver																																																											
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2011	Express/Savana	Body	Passenger Presence System																																																											
G	2011	Express/Savana	Body	Radio																																																										
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2011	Express/Savana	Body	Rollover Sensor																																																											
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2011	Express/Savana	Body	Theft Deterrent Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2011	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2011	Express Access/Savana Pro	Body	Radio																																																									
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2012	Express/Savana	Body	Body Control Module																																																									
G	2012	Express/Savana	Body	Digital Radio Receiver																																																									
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2012	Express/Savana	Body	Passenger Presence System																																																									
G	2012	Express/Savana	Body	Radio																																																									
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2012	Express/Savana	Body	Rollover Sensor																																																									
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2012	Express/Savana	Body	Theft Deterrent Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2012	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2012	Express Access/Savana Pro	Body	Radio																																																									
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2013	Express/Savana	Body	Body Control Module																																																									
G	2013	Express/Savana	Body	Digital Radio Receiver																																																									
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2013	Express/Savana	Body	Navigation Radio																																																									
G	2013	Express/Savana	Body	Park Assist Module																																																									
G	2013	Express/Savana	Body	Passenger Presence System																																																									
G	2013	Express/Savana	Body	Radio																																																									
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2013	Express/Savana	Body	Rollover Sensor																																																									
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2013	Express/Savana	Body	Theft Deterrent Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2013	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																								
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																								
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2013	Express Access/Savana Pro	Body	Radio																																																								
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																								
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																								
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																				V																																				
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																								
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																				V																																				
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																								
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																								
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2014	Express	Chassis	Electronic Brake Control Module																																																								
G	2014	Express	Body	Body Control Module						V	V	V						V					V	V																																				
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V			V	V																										
G	2014	Express	Body	Passenger Presence Module																										V																														
G	2014	Express	Body	Rollover Sensor Module																																																								
G	2014	Express	Body	Instrument Cluster																																																								
G	2014	Express	Body	Chime Alarm Control Module																																																								
G	2014	Express	Body	Base Radio																																																								
G	2014	Express	Body	Navigation Radio																																																								
G	2014	Express	Body	Uplevel Radio																																																								
G	2014	Express	Body	Digital Radio Receiver Control Module																																																								
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
G	2014	Express	Body	Auxiliary Heater Control Module																																																								
G	2014	Express	Body	Remote Control Door Lock Receiver																																																								
G	2014	Express	Body	Parking Assist Control Module																																V																								
G	2014	Express	Body	Theft Deterrent Module										V																																														

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																											
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																				V																																							
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																				V																																							
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																											
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																											
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																							
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																							
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
G	2014	Savana	Chassis	Electronic Brake Control Module																																																											
G	2014	Savana	Body	Body Control Module						V	V	V						V					V	V																																							
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V			V	V																													
G	2014	Savana	Body	Passenger Presence Module																										V																																
G	2014	Savana	Body	Rollover Sensor Module																																																										
G	2014	Savana	Body	Instrument Cluster																																																										
G	2014	Savana	Body	Chime Alarm Control Module																																																										
G	2014	Savana	Body	Base Radio																																																									
G	2014	Savana	Body	Navigation Radio																																																									
G	2014	Savana	Body	Uplevel Radio																																																									
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																						
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
G	2014	Savana	Body	Auxiliary Heater Control Module																																																										
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
G	2014	Savana	Body	Parking Assist Control Module																																V																										
G	2014	Savana	Body	Theft Deterrent Module										V																																																
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																				V																																							
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																							
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																							
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
G	2015	Express	Chassis	Electronic Brake Control Module																																																											
G	2015	Express	Body	Body Control Module						V	V	V						V					V	V																																							
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V			V	V																													
G	2015	Express	Body	Rollover Sensor Module																																																										
G	2015	Express	Body	Instrument Cluster																																																										
G	2015	Express	Body	Digital Radio Receiver Control Module																																																										
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																						
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
G	2015	Express	Body	Auxiliary Heater Control Module																																																										
G	2015	Express	Body	Remote Control Door Lock Receiver																																																										
G	2015	Express	Body	Parking Assist Control Module																																V																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2015	Express	Body	Theft Deterrent Module										V																																														
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																				V																																				
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2015	Savana	Chassis	Electronic Brake Control Module																																																								
G	2015	Savana	Body	Body Control Module						V	V	V					V					V	V																																					
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V		V	V																												
G	2015	Savana	Body	Rollover Sensor Module																																																								
G	2015	Savana	Body	Instrument Cluster																																																								
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																								
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																					
G	2015	Savana	Body	Auxiliary Heater Control Module																																																								
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																								
G	2015	Savana	Body	Parking Assist Control Module																																V																								
G	2015	Savana	Body	Theft Deterrent Module										V																																														
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																				V																																				
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2016	Express	Chassis	Electronic Brake Control Module																																																								
G	2016	Express	Body	Body Control Module						V	V	V					V					V	V																																					
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																											
G	2016	Express	Body	Instrument Cluster																																																								
G	2016	Express	Body	Chime Alarm Control Module																																																								
G	2016	Express	Body	Base Radio																																																								
G	2016	Express	Body	Navigation Radio																																																								
G	2016	Express	Body	Uplevel Radio																																																								
G	2016	Express	Body	Digital Radio Receiver Control Module																																																								
G	2016	Express	Body	Telematics Communication Interface Control Module																																V	V	V																						
G	2016	Express	Body	Auxiliary Heater Control Module																																																								
G	2016	Express	Body	Remote Control Door Lock Receiver																																																								
G	2016	Express	Body	Parking Assist Control Module																																V																								
G	2016	Express	Body	Theft Deterrent Module										V																																														
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																				V																																				
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2016	Savana	Chassis	Electronic Brake Control Module																																																								
G	2016	Savana	Body	Body Control Module						V	V	V						V					V	V																																				
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
G	2016	Savana	Body	Instrument Cluster																																																								
G	2016	Savana	Body	Chime Alarm Control Module																																																								
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																								
G	2016	Savana	Body	Telematics Communication Interface Control Module																																	V	V	V																					
G	2016	Savana	Body	Auxiliary Heater Control Module																																																								
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																								
G	2016	Savana	Body	Parking Assist Control Module																																V																								
G	2016	Savana	Body	Theft Deterrent Module										V																																														
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2004	Express/Savana	Chassis	VSES																																																								
H	2004	Express/Savana	Body	Body Control Module																														V																										
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2004	Express/Savana	Body	OnStar																																V																								
H	2004	Express/Savana	Body	Base Radio																																																								
H	2004	Express/Savana	Body	Uplevel Radio																																																								
H	2004	Express/Savana	Body	Remote Function Actuation																																																								
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2004	Express Access/Savana Pro	Chassis	VSES																																																								
H	2004	Express Access/Savana Pro	Body	Body Control Module																														V																										
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2004	Express Access/Savana Pro	Body	OnStar																																V																								
H	2004	Express Access/Savana Pro	Body	Base Radio																																																								
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2005	Express/Savana	Chassis	VSES																																																								
H	2005	Express/Savana	Body	Body Control Module																														V																										
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2005	Express/Savana	Body	Base Radio																																																								
H	2005	Express/Savana	Body	Uplevel Radio																																																								
H	2005	Express/Savana	Body	Remote Function Actuation																																																								
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																	V																							
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																							
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																						
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																						
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																						
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																						
H	2005	Express Access/Savana Pro	Chassis	VSES																																																						
H	2005	Express Access/Savana Pro	Body	Body Control Module																														V																										
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																						
H	2005	Express Access/Savana Pro	Body	Base Radio																																																						
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																						
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																						
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																					
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																	V																						
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																						
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																						
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																						
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																						
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																						
H	2006	Express/Savana	Chassis	VSES																																																					
H	2006	Express/Savana	Body	Body Control Module																														V																									
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																						
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																						
H	2006	Express/Savana	Body	Passenger Presence System																																																						
H	2006	Express/Savana	Body	Base Radio																																																						
H	2006	Express/Savana	Body	Uplevel Radio																																																						
H	2006	Express/Savana	Body	Remote Function Actuation																																																						
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																						
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																	V																						
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																						
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																						
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																						
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																						
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																						
H	2006	Express Access/Savana Pro	Chassis	VSES																																																						
H	2006	Express Access/Savana Pro	Body	Body Control Module																														V																									
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																						
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																						
H	2006	Express Access/Savana Pro	Body	Base Radio																																																						
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																						
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																						
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																						
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																	V																						
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																						
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																						
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																						
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																						
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																						
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2007	Express/Savana	Body	Body Control Module																														V																										
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2007	Express/Savana	Body	Passenger Presence System																																																								
H	2007	Express/Savana	Body	Base Radio																																																								
H	2007	Express/Savana	Body	Uplevel Radio																																																								
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																V																								
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2007	Express Access/Savana Pro	Body	Body Control Module																														V																										
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2007	Express Access/Savana Pro	Body	Base Radio																																																								
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																V																								
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2008	Express/Savana	Body	Body Control Module																																																								
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2008	Express/Savana	Body	Passenger Presence System																																																								
H	2008	Express/Savana	Body	Radio																																																								
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2008	Express/Savana	Body	Rollover Sensor																																																								
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2008	Express/Savana	Body	Theft Deterrent Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module																																																										
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																																										
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express/Savana	Body	Theft Deterrent Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express/Savana	Body	Body Control Module																																																										
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2010	Express/Savana	Body	Passenger Presence System																																																										
H	2010	Express/Savana	Body	Radio																																																									
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express/Savana	Body	Rollover Sensor																																																										
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express/Savana	Body	Theft Deterrent Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2010	Express Access/Savana Pro	Body	Radio																																																										
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2011	Express/Savana	Body	Body Control Module																																																										
H	2011	Express/Savana	Body	Digital Radio Receiver																																																										
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2011	Express/Savana	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2011	Express/Savana	Body	Radio																																																								
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2011	Express/Savana	Body	Rollover Sensor																																																								
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2011	Express/Savana	Body	Theft Deterrent Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2011	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2011	Express Access/Savana Pro	Body	Radio																																																								
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2012	Express/Savana	Body	Body Control Module																																																								
H	2012	Express/Savana	Body	Digital Radio Receiver																																																								
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2012	Express/Savana	Body	Passenger Presence System																																																								
H	2012	Express/Savana	Body	Radio																																																								
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2012	Express/Savana	Body	Rollover Sensor																																																								
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2012	Express/Savana	Body	Theft Deterrent Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2012	Express Access/Savana Pro	Body	Radio																																																									
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2013	Express/Savana	Body	Body Control Module																																																									
H	2013	Express/Savana	Body	Digital Radio Receiver																																																									
H	2013	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2013	Express/Savana	Body	Navigation Radio																																																									
H	2013	Express/Savana	Body	Park Assist Module																																																									
H	2013	Express/Savana	Body	Passenger Presence System																																																									
H	2013	Express/Savana	Body	Radio																																																									
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2013	Express/Savana	Body	Rollover Sensor																																																									
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2013	Express/Savana	Body	Theft Deterrent Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2013	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2013	Express Access/Savana Pro	Body	Navigation Radio																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2013	Express Access/Savana Pro	Body	Radio																																																										
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																				V																																						
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																				V																																						
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																						
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																						
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2014	Express	Chassis	Electronic Brake Control Module																																																										
H	2014	Express	Body	Body Control Module						V	V	V						V					V	V																																						
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V			V	V																												
H	2014	Express	Body	Passenger Presence Module																										V																																
H	2014	Express	Body	Rollover Sensor Module																																																										
H	2014	Express	Body	Instrument Cluster																																																										
H	2014	Express	Body	Chime Alarm Control Module																																																										
H	2014	Express	Body	Base Radio																																																										
H	2014	Express	Body	Navigation Radio																																																										
H	2014	Express	Body	Uplevel Radio																																																										
H	2014	Express	Body	Digital Radio Receiver Control Module																																																										
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																							
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																								
H	2014	Express	Body	Auxiliary Heater Control Module																																																										
H	2014	Express	Body	Remote Control Door Lock Receiver																																																										
H	2014	Express	Body	Parking Assist Control Module																																V																										
H	2014	Express	Body	Theft Deterrent Module										V																																																
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																				V																																						
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																				V																																						
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																						
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																						
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
H	2014	Savana	Chassis	Electronic Brake Control Module																																																									
H	2014	Savana	Body	Body Control Module						V	V	V						V					V	V																																					
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V			V	V																											
H	2014	Savana	Body	Passenger Presence Module																										V																															
H	2014	Savana	Body	Rollover Sensor Module																																																								
H	2014	Savana	Body	Instrument Cluster																																																								
H	2014	Savana	Body	Chime Alarm Control Module																																																								
H	2014	Savana	Body	Base Radio																																																								
H	2014	Savana	Body	Navigation Radio																																																								
H	2014	Savana	Body	Uplevel Radio																																																								
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																								
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																					
H	2014	Savana	Body	Auxiliary Heater Control Module																																																								
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																								
H	2014	Savana	Body	Parking Assist Control Module																															V																									
H	2014	Savana	Body	Theft Deterrent Module										V																																														
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																				V																																					
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																					
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																					
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
H	2015	Express	Chassis	Electronic Brake Control Module																																																								
H	2015	Express	Body	Body Control Module						V	V	V						V					V	V																																					
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V			V	V																											
H	2015	Express	Body	Rollover Sensor Module																																																								
H	2015	Express	Body	Instrument Cluster																																																								
H	2015	Express	Body	Digital Radio Receiver Control Module																																																								
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																					
H	2015	Express	Body	Auxiliary Heater Control Module																																																								
H	2015	Express	Body	Remote Control Door Lock Receiver																																																								
H	2015	Express	Body	Parking Assist Control Module																																V																								
H	2015	Express	Body	Theft Deterrent Module										V																																														
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																				V																																					
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																					
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																					
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
H	2015	Savana	Chassis	Electronic Brake Control Module																																																								
H	2015	Savana	Body	Body Control Module						V	V	V						V					V	V																																					
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V			V	V																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2015	Savana	Body	Rollover Sensor Module																																																									
H	2015	Savana	Body	Instrument Cluster																																																									
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																									
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																				
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																				
H	2015	Savana	Body	Auxiliary Heater Control Module																																																								
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																								
H	2015	Savana	Body	Parking Assist Control Module																																V																								
H	2015	Savana	Body	Theft Deterrent Module										V																																														
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																				V																																				
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
H	2016	Express	Chassis	Electronic Brake Control Module																																																								
H	2016	Express	Body	Body Control Module						V	V	V						V					V	V																																					
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
H	2016	Express	Body	Instrument Cluster																																																								
H	2016	Express	Body	Chime Alarm Control Module																																																								
H	2016	Express	Body	Base Radio																																																								
H	2016	Express	Body	Navigation Radio																																																								
H	2016	Express	Body	Uplevel Radio																																																								
H	2016	Express	Body	Digital Radio Receiver Control Module																																																								
H	2016	Express	Body	Telematics Communication Interface Control Module																																V	V	V																							
H	2016	Express	Body	Auxiliary Heater Control Module																																																								
H	2016	Express	Body	Remote Control Door Lock Receiver																																																								
H	2016	Express	Body	Parking Assist Control Module																																V																								
H	2016	Express	Body	Theft Deterrent Module										V																																														
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																				V																																				
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
H	2016	Savana	Chassis	Electronic Brake Control Module																																																								
H	2016	Savana	Body	Body Control Module						V	V	V						V					V	V																																					
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
H	2016	Savana	Body	Instrument Cluster																																																								
H	2016	Savana	Body	Chime Alarm Control Module																																																								
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																								
H	2016	Savana	Body	Telematics Communication Interface Control Module																																V	V	V																							
H	2016	Savana	Body	Auxiliary Heater Control Module																																																								
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																								
H	2016	Savana	Body	Parking Assist Control Module																																V																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2016	Savana	Body	Theft Deterrent Module										V																																																	
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																												
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																												
J	2004	ALL	Chassis	Electronic Brake Control Module																																																												
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																												
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																												
J	2007	ALL	Chassis	Electronic Brake Control Module																																																												
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																							
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																				V																																							
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																				V																																							
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																							
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																				V																																							
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																				V																																							
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																				V																																							
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																				V																																							
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																				V																																							
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																				V																																							
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																				V																																							
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																				V																																							
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																												
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																																												
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																												
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2013	Tracker	Chassis	Power Steering Control Module																																																												
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module				V	V																																																						
J	2013	Tracker	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V	V	V	V																								V									
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
J	2013	Tracker	Body	Passenger Presence Module																																V																											
J	2013	Tracker	Body	Instrument Cluster																																	V																									
J	2013	Tracker	Body	Radio																																																										
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																		V	V	V	V																				
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																											V													
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V													
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																											V													
J	2013	Tracker	Body	Front Seat Heating Control Module																																					V	V																			
J	2013	Tracker	Body	Parking Assist Control Module																																	V																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2013	Tracker	Body	Frontview Camera Module																																																											
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																							
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																				V																																							
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																				V																																							
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																							
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																				V																																							
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																				V																																							
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																								
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																				V																																								
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																				V																																								
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																				V																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																				V																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																				V																																								
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
J	2013	Trax	Chassis	Electronic Brake Control Module																																																												
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2013	Trax	Chassis	Power Steering Control Module																																																												
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module				V	V																																																						
J	2013	Trax	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V	V	V	V																								V									
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
J	2013	Trax	Body	Passenger Presence Module																																V																											
J	2013	Trax	Body	Instrument Cluster																																	V																								
J	2013	Trax	Body	Radio																																																										
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																				
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																											V													
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V													
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																											V													
J	2013	Trax	Body	Front Seat Heating Control Module																																						V	V																		
J	2013	Trax	Body	Parking Assist Control Module																																V																									
J	2013	Trax	Body	Frontview Camera Module																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																							
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																				V																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																				V																																						
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																				V																																						
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																				V																																						
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																						
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																				V																																						
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																				V																																						
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																				V																																						
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																				V																																						
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																				V																																						
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																				V																																						
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																				V																																						
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																				V																																						
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2014	Tracker	Chassis	Power Steering Control Module																																																										
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
J	2014	Tracker	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V	V	V	V																							V								
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2014	Tracker	Body	Passenger Presence Module																																V																									
J	2014	Tracker	Body	Instrument Cluster																																	V																							
J	2014	Tracker	Body	Radio																																																									
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																		V	V	V	V																			
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																												V											
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																												V											
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																												V											
J	2014	Tracker	Body	Front Seat Heating Control Module																																					V	V																			
J	2014	Tracker	Body	Parking Assist Control Module																																	V																							
J	2014	Tracker	Body	Frontview Camera Module																																																									
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																						
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																								
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																				
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																				V																																				
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																								
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																								
J	2014	Trax	Chassis	Electronic Brake Control Module																																																								
J	2014	Trax	Chassis	Power Steering Control Module																																																								
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
J	2014	Trax	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V	V	V	V																															V			
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2014	Trax	Body	Passenger Presence Module																															V																									
J	2014	Trax	Body	Instrument Cluster																																V																								
J	2014	Trax	Body	Radio																																																								
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V	V																				
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																										V														
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																										V														
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																										V														
J	2014	Trax	Body	Front Seat Heating Control Module																																					V	V																		
J	2014	Trax	Body	Parking Assist Control Module																																V																								
J	2014	Trax	Body	Frontview Camera Module																																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																				V																																				
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																				V																																				
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																				
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																				V																																				
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																				V																																				
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																				V																																				
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																				V																																			
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																				V																																			
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																				V																																			
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																				V																																			
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																				V																																			
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																								
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																																								
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																								
J	2015	Tracker	Chassis	Power Steering Control Module																																																								
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module			V	V																																																				
J	2015	Tracker	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V	V	V	V																										V						
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
J	2015	Tracker	Body	Instrument Cluster																																V																								
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																	V	V	V																					
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																											V													
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																											V													
J	2015	Tracker	Body	Front Seat Heating Control Module																																				V	V																		
J	2015	Tracker	Body	Parking Assist Control Module																																V																							
J	2015	Tracker	Body	Frontview Camera Module																																																								
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																			
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																			
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																			
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																								
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																								
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																								
J	2015	Trax	Powertrain	Chassis Control Module																																																								
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																								
J	2015	Trax	Chassis	Electronic Brake Control Module																																																								
J	2015	Trax	Chassis	Power Steering Control Module																																																								
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module			V	V																																																				
J	2015	Trax	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V	V	V	V																										V						
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
J	2015	Trax	Body	Passenger Presence Module																															V																									
J	2015	Trax	Body	Instrument Cluster																																V																							
J	2015	Trax	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																		V	V	V																				
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																											V											
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																											V											
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																											V											
J	2015	Trax	Body	Seat Memory Control Module																																																						
J	2015	Trax	Body	Front Seat Heating Control Module																																					V	V																		
J	2015	Trax	Body	Right Side Object Detection Control Module																																																						
J	2015	Trax	Body	Left Side Object Detection Control Module																																																						
J	2015	Trax	Body	Parking Assist Control Module																																V																							
J	2015	Trax	Body	Frontview Camera Module																																																						
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																			
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																						
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																						
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																			
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																						
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																						
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																				V																																			
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																						
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																						
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																						
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																				V																																			
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																				V																																			
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																						
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																						
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																						
J	2016	Tracker	Chassis	Power Steering Control Module																																																						
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
J	2016	Tracker	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V	V	V	V																												V				
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
J	2016	Tracker	Body	Instrument Cluster																																V																							
J	2016	Tracker	Body	Trailer Interface Control Module																																V																							
J	2016	Tracker	Body	Radio																																																						
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																		V	V	V																				
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																											V											
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																											V											
J	2016	Tracker	Body	Front Seat Heating Control Module																																					V	V																		
J	2016	Tracker	Body	Parking Assist Control Module																																V																							
J	2016	Tracker	Body	Frontview Camera Module																																																						
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																				V																																			
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																				V																																			
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																						
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																				V																																			
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																						
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																			
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																						
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																						
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																				V																																			
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																						
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																				V																																				
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																								
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																				V																																				
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																								
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																								
J	2016	Trax	Powertrain	Chassis Control Module																																																								
J	2016	Trax	Chassis	Electronic Brake Control Module																																																								
J	2016	Trax	Chassis	Power Steering Control Module																																																								
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
J	2016	Trax	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V	V	V	V																										V						
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
J	2016	Trax	Body	Passenger Presence Module																																V																								
J	2016	Trax	Body	Instrument Cluster																																	V																							
J	2016	Trax	Body	Trailer Interface Control Module																																	V																							
J	2016	Trax	Body	Radio																																																								
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																		V	V	V																				
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																			
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																												V											
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																												V											
J	2016	Trax	Body	Seat Memory Control Module																																																								
J	2016	Trax	Body	Front Seat Heating Control Module																																						V	V																		
J	2016	Trax	Body	Right Side Object Detection Control Module																																																								
J	2016	Trax	Body	Left Side Object Detection Control Module																																																								
J	2016	Trax	Body	Parking Assist Control Module																																	V																							
J	2016	Trax	Body	Frontview Camera Module																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																										
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2004	ALL	Chassis	ESC																																																									
K	2004	ALL	Chassis	Rear Wheel Steering																																																										
K	2004	ALL	Chassis	Tire Pressure Monitor																																																										
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2004	ALL	Chassis	VSES																																																									
K	2004	ALL	Body	Amplifier (Bose)																																																										
K	2004	ALL	Body	Body Control Module																														V																												
K	2004	ALL	Body	CD Changer																																																										
K	2004	ALL	Body	Chime																																																										
K	2004	ALL	Body	Driver Door Module																																																										
K	2004	ALL	Body	Driver Seat Module																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2004	ALL	Body	Instrument Panel Cluster																																																										
K	2004	ALL	Body	OnStar																																	V																							
K	2004	ALL	Body	Passenger Door Module																																																										
K	2004	ALL	Body	Passenger Presence System																																																										
K	2004	ALL	Body	Radio Base																																																										
K	2004	ALL	Body	Radio Uplevel																																																										
K	2004	ALL	Body	Radio Navigation																																																										
K	2004	ALL	Body	Rear Aux. Climate Module																																																										
K	2004	ALL	Body	Rear HVAC																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2004	ALL	Body	Rear Seat Audio																																																									
K	2004	ALL	Body	Rear Seat Entertainment																																																									
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2004	ALL	Body	Vehicle Theft Deterrent																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																								
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																								
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
K	2005	ALL	Chassis	ESC																																																								
K	2005	ALL	Chassis	Rear Wheel Steering																																																								
K	2005	ALL	Chassis	Tire Pressure Monitor																																																								
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																								
K	2005	ALL	Chassis	VSES																																																								
K	2005	ALL	Body	Amplifier (Bose)																																																								
K	2005	ALL	Body	Body Control Module																															V																									
K	2005	ALL	Body	CD Changer																																																								
K	2005	ALL	Body	Chime																																																								
K	2005	ALL	Body	Disc Player and Video Display																																																								
K	2005	ALL	Body	Driver Door Module																																																								
K	2005	ALL	Body	Driver Seat Module																																																								
K	2005	ALL	Body	Generator Battery Control Module																																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																								
K	2005	ALL	Body	Instrument Panel Cluster																																																								
K	2005	ALL	Body	Passenger Door Module																																																								
K	2005	ALL	Body	Passenger Presence System																																																								
K	2005	ALL	Body	Base Radio																																																								
K	2005	ALL	Body	Uplevel Radio																																																								
K	2005	ALL	Body	Navigation Radio																																																								
K	2005	ALL	Body	Rear Aux. Climate Module																																																								
K	2005	ALL	Body	Rear HVAC																																																								
K	2005	ALL	Body	Rear Seat Audio																																																								
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2005	ALL	Body	Vehicle Comm. Interface Module																																	V																							
K	2005	ALL	Body	Vehicle Theft Deterrent																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																								
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																									
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
K	2006	ALL	Chassis	ESC																																																								
K	2006	ALL	Chassis	Tire Pressure Monitor																																																								
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																								
K	2006	ALL	Chassis	VSES																																																								
K	2006	ALL	Body	Amplifier (Bose)																																																								
K	2006	ALL	Body	Body Control Module																														V																											
K	2006	ALL	Body	CD Changer																																																								
K	2006	ALL	Body	Chime																																																								
K	2006	ALL	Body	Disc Player and Video Display																																																								
K	2006	ALL	Body	Driver Door Module																																																								
K	2006	ALL	Body	Driver Seat Module																																																								
K	2006	ALL	Body	Generator Battery Control Module																																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																								
K	2006	ALL	Body	Instrument Panel Cluster																																																								
K	2006	ALL	Body	Passenger Door Module																																																								
K	2006	ALL	Body	Passenger Presence System																																																								
K	2006	ALL	Body	Base Radio																																																								
K	2006	ALL	Body	Uplevel Radio																																																								
K	2006	ALL	Body	Navigation Radio																																																								
K	2006	ALL	Body	Rear Aux. Climate Module																																																								
K	2006	ALL	Body	Rear HVAC																																																								
K	2006	ALL	Body	Rear Seat Audio																																																								
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2006	ALL	Body	Vehicle Theft Deterrent																																																								
K	2006	ALL	Body	Vehicle Comm. Interface Module																																	V																							
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2007	Avalanche	Chassis	Electronic Suspension Control																																																								
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																																								
K	2007	Avalanche	Body	Amplifier (Bose)																																																								
K	2007	Avalanche	Body	Assist Step Controller																																																								
K	2007	Avalanche	Body	Body Control Module																																																								
K	2007	Avalanche	Body	Body Control Module (aux.)																																																								
K	2007	Avalanche	Body	Digital Radio Receiver																																																								
K	2007	Avalanche	Body	Driver Door Switch																																																								
K	2007	Avalanche	Body	HVAC Control Module Auto																																												V												
K	2007	Avalanche	Body	HVAC Control Module Manual																																												V												
K	2007	Avalanche	Body	Instrument Panel Cluster																																																								
K	2007	Avalanche	Body	Memory Seat Module																																																								
K	2007	Avalanche	Body	Park Assist Module																																																								
K	2007	Avalanche	Body	Passenger Door Switch																																																								
K	2007	Avalanche	Body	Passenger Presence System																																																								
K	2007	Avalanche	Body	Radio																																																								
K	2007	Avalanche	Body	Rear Heated Seat Module																																																								
K	2007	Avalanche	Body	Rear HVAC/RSA																																																								
K	2007	Avalanche	Body	Rollover Sensor																																																								
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																								
K	2007	Avalanche	Body	Theft Deterrent Module																																																								
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Suburban	Chassis	Electronic Suspension Control																																																												
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																												
K	2007	Suburban	Body	Amplifier (Bose)																																																												
K	2007	Suburban	Body	Assist Step Controller																																																												
K	2007	Suburban	Body	Body Control Module																																																												
K	2007	Suburban	Body	Body Control Module (aux.)																																																												
K	2007	Suburban	Body	Digital Radio Receiver																																																												
K	2007	Suburban	Body	Driver Door Switch																																																												
K	2007	Suburban	Body	HVAC Control Module Auto																																												V																
K	2007	Suburban	Body	HVAC Control Module Manual																																												V																
K	2007	Suburban	Body	Instrument Panel Cluster																																																												
K	2007	Suburban	Body	Lift Gate Module																																																												
K	2007	Suburban	Body	Memory Seat Module																																																												
K	2007	Suburban	Body	Park Assist Module																																																												
K	2007	Suburban	Body	Passenger Door Switch																																																												
K	2007	Suburban	Body	Passenger Presence System																																																												
K	2007	Suburban	Body	Radio																																																											
K	2007	Suburban	Body	Rear Heated Seat Module																																																												
K	2007	Suburban	Body	Rear HVAC/RSA																																																												
K	2007	Suburban	Body	Rollover Sensor																																																												
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2007	Suburban	Body	Theft Deterrent Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2007	Silverado	Chassis	Electronic Suspension Control																																																								
K	2007	Silverado	Chassis	Trailer Brake Control Module																																																								
K	2007	Silverado	Body	Amplifier (Bose)																																																								
K	2007	Silverado	Body	Body Control Module																																																								
K	2007	Silverado	Body	Body Control Module (aux.)																																																								
K	2007	Silverado	Body	Digital Radio Receiver																																																								
K	2007	Silverado	Body	Driver Door Switch																																																								
K	2007	Silverado	Body	HVAC Control Module Auto																																													V											
K	2007	Silverado	Body	HVAC Control Module Manual																																													V											
K	2007	Silverado	Body	Instrument Panel Cluster																																																								
K	2007	Silverado	Body	Memory Seat Module																																																								
K	2007	Silverado	Body	Park Assist Module																																																								
K	2007	Silverado	Body	Passenger Door Switch																																																								
K	2007	Silverado	Body	Passenger Presence System																																																								
K	2007	Silverado	Body	Radio																																																								
K	2007	Silverado	Body	Rear Heated Seat Module																																																								
K	2007	Silverado	Body	Rear HVAC/RSA																																																								
K	2007	Silverado	Body	Rollover Sensor																																																								
K	2007	Silverado	Body	Supplemental Inflatable Restraint																																																								
K	2007	Silverado	Body	Theft Deterrent Module																																																								
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																								
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																								
K	2007	Tahoe	Body	Amplifier (Bose)																																																								
K	2007	Tahoe	Body	Assist Step Controller																																																								
K	2007	Tahoe	Body	Body Control Module																																																								
K	2007	Tahoe	Body	Body Control Module (aux.)																																																								
K	2007	Tahoe	Body	Digital Radio Receiver																																																								
K	2007	Tahoe	Body	Driver Door Switch																																																								
K	2007	Tahoe	Body	HVAC Control Module Auto																																												V												
K	2007	Tahoe	Body	HVAC Control Module Manual																																												V												
K	2007	Tahoe	Body	Instrument Panel Cluster																																																								
K	2007	Tahoe	Body	Lift Gate Module																																																								
K	2007	Tahoe	Body	Memory Seat Module																																																								
K	2007	Tahoe	Body	Park Assist Module																																																								
K	2007	Tahoe	Body	Passenger Door Switch																																																								
K	2007	Tahoe	Body	Passenger Presence System																																																								
K	2007	Tahoe	Body	Radio																																																								
K	2007	Tahoe	Body	Rear Heated Seat Module																																																								
K	2007	Tahoe	Body	Rear HVAC/RSA																																																								
K	2007	Tahoe	Body	Rollover Sensor																																																								
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																								
K	2007	Tahoe	Body	Theft Deterrent Module																																																								
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2008	Avalanche	Chassis	Electronic Brake Control Module																																																								
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																								
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																								
K	2008	Avalanche	Body	Amplifier (Bose)																																																								
K	2008	Avalanche	Body	Assist Step Controller																																																								
K	2008	Avalanche	Body	Body Control Module																																																								
K	2008	Avalanche	Body	Body Control Module (aux.)																																																								
K	2008	Avalanche	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2008	Avalanche	Body	Driver Door Switch																																																								
K	2008	Avalanche	Body	HVAC Control Module Auto																																																								
K	2008	Avalanche	Body	HVAC Control Module Manual																																																								
K	2008	Avalanche	Body	Instrument Panel Cluster																																																								
K	2008	Avalanche	Body	Memory Seat Module																																																								
K	2008	Avalanche	Body	Park Assist Module																																																								
K	2008	Avalanche	Body	Passenger Door Switch																																																								
K	2008	Avalanche	Body	Passenger Presence System																																																								
K	2008	Avalanche	Body	Radio																																																								
K	2008	Avalanche	Body	Rear Heated Seat Module																																																								
K	2008	Avalanche	Body	Rear HVAC/RSA																																																								
K	2008	Avalanche	Body	Rollover Sensor																																																								
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																								
K	2008	Avalanche	Body	Theft Deterrent Module																																																								
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2008	Suburban	Chassis	EBCM Under 8600 GVW																																																								
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2008	Suburban	Chassis	Electronic Suspension Control																																																								
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																								
K	2008	Suburban	Body	Amplifier (Bose)																																																								
K	2008	Suburban	Body	Assist Step Controller																																																								
K	2008	Suburban	Body	Body Control Module																																																								
K	2008	Suburban	Body	Body Control Module (aux.)																																																								
K	2008	Suburban	Body	Digital Radio Receiver																																																								
K	2008	Suburban	Body	Driver Door Switch																																																								
K	2008	Suburban	Body	HVAC Control Module Auto																																																								
K	2008	Suburban	Body	HVAC Control Module Manual																																																								
K	2008	Suburban	Body	Instrument Panel Cluster																																																								
K	2008	Suburban	Body	Lift Gate Module																																																								
K	2008	Suburban	Body	Memory Seat Module																																																								
K	2008	Suburban	Body	Park Assist Module																																																								
K	2008	Suburban	Body	Passenger Door Switch																																																								
K	2008	Suburban	Body	Passenger Presence System																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2008	Suburban	Body	Radio																																																								
K	2008	Suburban	Body	Rear Heated Seat Module																																																								
K	2008	Suburban	Body	Rear HVAC/RSA																																																								
K	2008	Suburban	Body	Rollover Sensor																																																								
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																																								
K	2008	Suburban	Body	Theft Deterrent Module																																																								
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2008	Silverado	Chassis	Electronic Suspension Control																																																								
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																								
K	2008	Silverado	Body	Amplifier (Bose)																																																								
K	2008	Silverado	Body	Body Control Module																																																								
K	2008	Silverado	Body	Body Control Module (aux.)																																																								
K	2008	Silverado	Body	Digital Radio Receiver																																																								
K	2008	Silverado	Body	Driver Door Switch																																																								
K	2008	Silverado	Body	HVAC Control Module Auto																																												V												
K	2008	Silverado	Body	HVAC Control Module Manual																																												V												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2008	Silverado	Body	Instrument Panel Cluster																																																									
K	2008	Silverado	Body	Memory Seat Module																																																										
K	2008	Silverado	Body	Park Assist Module																																																										
K	2008	Silverado	Body	Passenger Door Switch																																																										
K	2008	Silverado	Body	Passenger Presence System																																																										
K	2008	Silverado	Body	Radio																																																										
K	2008	Silverado	Body	Rear Heated Seat Module																																																											
K	2008	Silverado	Body	Rear HVAC/RSA																																																											
K	2008	Silverado	Body	Rollover Sensor																																																											
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																																											
K	2008	Silverado	Body	Theft Deterrent Module																																																											
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
K	2008	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																											
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																											
K	2008	Tahoe	Body	Amplifier (Bose)																																																											
K	2008	Tahoe	Body	Assist Step Controller																																																											
K	2008	Tahoe	Body	Body Control Module																																																											
K	2008	Tahoe	Body	Body Control Module (aux.)																																																											
K	2008	Tahoe	Body	Digital Radio Receiver																																																											
K	2008	Tahoe	Body	Driver Door Switch																																																											
K	2008	Tahoe	Body	HVAC Control Module Auto																																												V															
K	2008	Tahoe	Body	HVAC Control Module Manual																																												V															
K	2008	Tahoe	Body	Instrument Panel Cluster																																																											
K	2008	Tahoe	Body	Lift Gate Module																																																											
K	2008	Tahoe	Body	Memory Seat Module																																																											
K	2008	Tahoe	Body	Park Assist Module																																																											
K	2008	Tahoe	Body	Passenger Door Switch																																																											
K	2008	Tahoe	Body	Passenger Presence System																																																											
K	2008	Tahoe	Body	Radio																																																										
K	2008	Tahoe	Body	Rear Heated Seat Module																																																											
K	2008	Tahoe	Body	Rear HVAC/RSA																																																											
K	2008	Tahoe	Body	Rollover Sensor																																																											
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																											
K	2008	Tahoe	Body	Theft Deterrent Module																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																								
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																								
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																								
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
K	2008	Tahoe Hybrid	Body	Body Control Module																																																								
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																																								
K	2008	Tahoe Hybrid	Body	HVAC Control Module																																																								
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																								
K	2008	Tahoe Hybrid	Body	Memory Seat Module																																																								
K	2008	Tahoe Hybrid	Body	Park Assist Module																																																								
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																								
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																																								
K	2008	Tahoe Hybrid	Body	Radio																																																								
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																								
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																								
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																								
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																								
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2009	Avalanche	Chassis	Electronic Brake Control Module																																																								
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																												
K	2009	Avalanche	Body	Amplifier (Bose)																																																													
K	2009	Avalanche	Body	Assist Step Controller																																																													
K	2009	Avalanche	Body	Body Control Module																																																													
K	2009	Avalanche	Body	Body Control Module (aux.)																																																													
K	2009	Avalanche	Body	Digital Radio Receiver																																																													
K	2009	Avalanche	Body	Driver Door Switch																																																													
K	2009	Avalanche	Body	HVAC Control Module Auto																																												V																
K	2009	Avalanche	Body	HVAC Control Module Manual																																												V																
K	2009	Avalanche	Body	Instrument Panel Cluster																																																													
K	2009	Avalanche	Body	Memory Seat Module																																																													
K	2009	Avalanche	Body	Park Assist Module																																																													
K	2009	Avalanche	Body	Passenger Door Switch																																																													
K	2009	Avalanche	Body	Passenger Presence System																																																													
K	2009	Avalanche	Body	Radio																																																													
K	2009	Avalanche	Body	Rear Heated Seat Module																																																													
K	2009	Avalanche	Body	Rear HVAC/RSA																																																													
K	2009	Avalanche	Body	Rollover Sensor																																																													
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																													
K	2009	Avalanche	Body	Theft Deterrent Module																																																													
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																													
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																													
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																													
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																													
K	2009	Cheyenne	Body	Amplifier (Bose)																																																													
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																													
K	2009	Cheyenne	Body	Digital Radio Receiver																																																													
K	2009	Cheyenne	Body	Driver Door Switch																																																													
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																													
K	2009	Cheyenne	Body	Park Assist Module																																																													
K	2009	Cheyenne	Body	Passenger Door Switch																																																													
K	2009	Cheyenne	Body	Passenger Presence System																																																													
K	2009	Cheyenne	Body	Rear Heated Seat Module																																																													
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																													
K	2009	Cheyenne	Body	Rollover Sensor																																																													
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																													
K	2009	Cheyenne	Body	Theft Deterrent Module																																																													
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2009	Suburban	Chassis	Electronic Suspension Control																																																										
K	2009	Suburban	Chassis	Trailer Brake Control Module																																																										
K	2009	Suburban	Body	Amplifier (Bose)																																																										
K	2009	Suburban	Body	Assist Step Controller																																																										
K	2009	Suburban	Body	Body Control Module																																																									
K	2009	Suburban	Body	Body Control Module (aux.)																																																										
K	2009	Suburban	Body	Digital Radio Receiver																																																										
K	2009	Suburban	Body	Driver Door Switch																																																										
K	2009	Suburban	Body	HVAC Control Module Auto																																												V														
K	2009	Suburban	Body	HVAC Control Module Manual																																												V														
K	2009	Suburban	Body	Instrument Panel Cluster																																																										
K	2009	Suburban	Body	Left Side Object Detection Module																																																										
K	2009	Suburban	Body	Lift Gate Module																																																										
K	2009	Suburban	Body	Memory Seat Module																																																										
K	2009	Suburban	Body	Park Assist Module																																																										
K	2009	Suburban	Body	Passenger Door Switch																																																										
K	2009	Suburban	Body	Passenger Presence System																																																										
K	2009	Suburban	Body	Radio																																																										
K	2009	Suburban	Body	Rear Heated Seat Module																																																										
K	2009	Suburban	Body	Rear HVAC/RSA																																																										
K	2009	Suburban	Body	Right Side Object Detection Module																																																										
K	2009	Suburban	Body	Rollover Sensor																																																										
K	2009	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2009	Suburban	Body	Theft Deterrent Module																																																										
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																												
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2009	Silverado	Chassis	Electronic Suspension Control																																																												
K	2009	Silverado	Chassis	Trailer Brake Control Module																																																												
K	2009	Silverado	Body	Amplifier (Bose)																																																												
K	2009	Silverado	Body	Body Control Module																																																												
K	2009	Silverado	Body	Body Control Module (aux.)																																																												
K	2009	Silverado	Body	Digital Radio Receiver																																																												
K	2009	Silverado	Body	Driver Door Switch																																																												
K	2009	Silverado	Body	HVAC Control Module Auto																																													V															
K	2009	Silverado	Body	HVAC Control Module Manual																																													V															
K	2009	Silverado	Body	Instrument Panel Cluster																																																												
K	2009	Silverado	Body	Memory Seat Module																																																												
K	2009	Silverado	Body	Park Assist Module																																																												
K	2009	Silverado	Body	Passenger Door Switch																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2009	Silverado	Body	Passenger Presence System																																																									
K	2009	Silverado	Body	Radio																																																									
K	2009	Silverado	Body	Rear Heated Seat Module																																																										
K	2009	Silverado	Body	Rear HVAC/RSA																																																										
K	2009	Silverado	Body	Rollover Sensor																																																										
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2009	Silverado	Body	Theft Deterrent Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Silverado Hybrid	Body	Body Control Module																																																										
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2009	Silverado Hybrid	Body	HVAC Control Module																																												V														
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Silverado Hybrid	Body	Memory Seat Module																																																										
K	2009	Silverado Hybrid	Body	Park Assist Module																																																										
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2009	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2009	Silverado Hybrid	Body	Radio																																																										
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																										
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2009	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																																												
K	2009	Tahoe	Body	Amplifier (Bose)																																																												
K	2009	Tahoe	Body	Assist Step Controller																																																												
K	2009	Tahoe	Body	Body Control Module																																																												
K	2009	Tahoe	Body	Body Control Module (aux.)																																																												
K	2009	Tahoe	Body	Digital Radio Receiver																																																												
K	2009	Tahoe	Body	Driver Door Switch																																																												
K	2009	Tahoe	Body	HVAC Control Module Auto																																											V																
K	2009	Tahoe	Body	HVAC Control Module Manual																																											V																
K	2009	Tahoe	Body	Instrument Panel Cluster																																																												
K	2009	Tahoe	Body	Left Side Object Detection Module																																																												
K	2009	Tahoe	Body	Lift Gate Module																																																												
K	2009	Tahoe	Body	Memory Seat Module																																																												
K	2009	Tahoe	Body	Park Assist Module																																																												
K	2009	Tahoe	Body	Passenger Door Switch																																																												
K	2009	Tahoe	Body	Passenger Presence System																																																												
K	2009	Tahoe	Body	Radio																																																												
K	2009	Tahoe	Body	Rear Heated Seat Module																																																												
K	2009	Tahoe	Body	Rear HVAC/RSA																																																												
K	2009	Tahoe	Body	Right Side Object Detection Module																																																												
K	2009	Tahoe	Body	Rollover Sensor																																																												
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2009	Tahoe	Body	Theft Deterrent Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																												
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
K	2009	Tahoe Hybrid	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																																								
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																																								
K	2009	Tahoe Hybrid	Body	HVAC Control Module																																																								
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
K	2009	Tahoe Hybrid	Body	Park Assist Module																																																								
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																								
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																																								
K	2009	Tahoe Hybrid	Body	Radio																																																								
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																								
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																								
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																								
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2010	Avalanche	Chassis	Electronic Brake Control Module																																																								
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																								
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Avalanche	Body	Amplifier (Bose)																																																								
K	2010	Avalanche	Body	Assist Step Controller																																																								
K	2010	Avalanche	Body	Body Control Module																																																								
K	2010	Avalanche	Body	Body Control Module (aux.)																																																								
K	2010	Avalanche	Body	Digital Radio Receiver																																																								
K	2010	Avalanche	Body	Driver Door Switch																																																								
K	2010	Avalanche	Body	HVAC Control Module Auto																																																								
K	2010	Avalanche	Body	HVAC Control Module Manual																																																								
K	2010	Avalanche	Body	Instrument Panel Cluster																																																								
K	2010	Avalanche	Body	Memory Seat Module																																																								
K	2010	Avalanche	Body	Park Assist Module																																																								
K	2010	Avalanche	Body	Passenger Door Switch																																																								
K	2010	Avalanche	Body	Passenger Presence System																																																								
K	2010	Avalanche	Body	Radio																																																								
K	2010	Avalanche	Body	Rear Heated Seat Module																																																								
K	2010	Avalanche	Body	Rear HVAC/RSA																																																								
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																									V	V																														
K	2010	Avalanche	Body	Theft Deterrent Module																																																								
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																											
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Cheyenne	Body	Amplifier (Bose)																																																											
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2010	Cheyenne	Body	Digital Radio Receiver																																																											
K	2010	Cheyenne	Body	Driver Door Switch																																																											
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2010	Cheyenne	Body	Park Assist Module																																																											
K	2010	Cheyenne	Body	Passenger Door Switch																																																											
K	2010	Cheyenne	Body	Passenger Presence System																																																											
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																											
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																									V	V																																	
K	2010	Cheyenne	Body	Theft Deterrent Module																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																											
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2010	Suburban	Chassis	Electronic Suspension Control																																																											
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Suburban	Body	Amplifier (Bose)																																																											
K	2010	Suburban	Body	Assist Step Controller																																																											
K	2010	Suburban	Body	Body Control Module																																																											
K	2010	Suburban	Body	Body Control Module (aux.)																																																											
K	2010	Suburban	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2010	Suburban	Body	Driver Door Switch																																																								
K	2010	Suburban	Body	HVAC Control Module Auto																																												V												
K	2010	Suburban	Body	HVAC Control Module Manual																																												V												
K	2010	Suburban	Body	Instrument Panel Cluster																																																								
K	2010	Suburban	Body	Left Side Object Detection Module																																																								
K	2010	Suburban	Body	Lift Gate Module																																																								
K	2010	Suburban	Body	Memory Seat Module																																																								
K	2010	Suburban	Body	Park Assist Module																																																								
K	2010	Suburban	Body	Passenger Door Switch																																																								
K	2010	Suburban	Body	Passenger Presence System																																																								
K	2010	Suburban	Body	Radio																																																								
K	2010	Suburban	Body	Rear Heated Seat Module																																																								
K	2010	Suburban	Body	Rear HVAC/RSA																																																								
K	2010	Suburban	Body	Right Side Object Detection Module																																																								
K	2010	Suburban	Body	Supplemental Inflatable Restraint																									V	V																														
K	2010	Suburban	Body	Theft Deterrent Module																																																								
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																								
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																								
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																								
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																								
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
K	2010	Silverado	Chassis	Electronic Suspension Control																																																										
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2010	Silverado	Body	Amplifier (Bose)																																																										
K	2010	Silverado	Body	Body Control Module																																																										
K	2010	Silverado	Body	Body Control Module (aux.)																																																										
K	2010	Silverado	Body	Digital Radio Receiver																																																										
K	2010	Silverado	Body	Driver Door Switch																																																										
K	2010	Silverado	Body	HVAC Control Module Auto																																													V														
K	2010	Silverado	Body	HVAC Control Module Manual																																													V														
K	2010	Silverado	Body	Instrument Panel Cluster																																																										
K	2010	Silverado	Body	Memory Seat Module																																																										
K	2010	Silverado	Body	Park Assist Module																																																										
K	2010	Silverado	Body	Passenger Door Switch																																																										
K	2010	Silverado	Body	Passenger Presence System																																																										
K	2010	Silverado	Body	Radio																																																										
K	2010	Silverado	Body	Rear Heated Seat Module																																																										
K	2010	Silverado	Body	Rear HVAC/RSA																																																										
K	2010	Silverado	Body	Supplemental Inflatable Restraint																									V	V																																
K	2010	Silverado	Body	Theft Deterrent Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Silverado Hybrid	Body	Body Control Module																																																										
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2010	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2010	Silverado Hybrid	Body	HVAC Control Module																																													V														
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Silverado Hybrid	Body	Park Assist Module																																																										
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2010	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2010	Silverado Hybrid	Body	Radio																																																										
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Tahoe	Body	Amplifier (Bose)																																																										
K	2010	Tahoe	Body	Assist Step Controller																																																										
K	2010	Tahoe	Body	Body Control Module																																																										
K	2010	Tahoe	Body	Body Control Module (aux.)																																																										
K	2010	Tahoe	Body	Digital Radio Receiver																																																										
K	2010	Tahoe	Body	Driver Door Switch																																																										
K	2010	Tahoe	Body	HVAC Control Module Auto																																													V													
K	2010	Tahoe	Body	HVAC Control Module Manual																																													V													
K	2010	Tahoe	Body	Instrument Panel Cluster																																																										
K	2010	Tahoe	Body	Left Side Object Detection Module																																																										
K	2010	Tahoe	Body	Lift Gate Module																																																										
K	2010	Tahoe	Body	Memory Seat Module																																																										
K	2010	Tahoe	Body	Park Assist Module																																																										
K	2010	Tahoe	Body	Passenger Door Switch																																																										
K	2010	Tahoe	Body	Passenger Presence System																																																										
K	2010	Tahoe	Body	Radio																																																										
K	2010	Tahoe	Body	Rear Heated Seat Module																																																										
K	2010	Tahoe	Body	Rear HVAC/RSA																																																										
K	2010	Tahoe	Body	Right Side Object Detection Module																																																										
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																									V	V																																
K	2010	Tahoe	Body	Theft Deterrent Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Tahoe Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2010	Tahoe Hybrid	Body	HVAC Control Module																																												V														
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2010	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2010	Tahoe Hybrid	Body	Radio																																																										
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2011	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Avalanche	Body	Amplifier (Bose)																																																										
K	2011	Avalanche	Body	Assist Step Controller																																																										
K	2011	Avalanche	Body	Body Control Module																																																										
K	2011	Avalanche	Body	Body Control Module (aux.)																																																										
K	2011	Avalanche	Body	Digital Radio Receiver																																																										
K	2011	Avalanche	Body	Driver Door Switch																																																										
K	2011	Avalanche	Body	HVAC Control Module Auto																																												V														
K	2011	Avalanche	Body	HVAC Control Module Manual																																												V														
K	2011	Avalanche	Body	Instrument Panel Cluster																																																										
K	2011	Avalanche	Body	Memory Seat Module																																																										
K	2011	Avalanche	Body	Park Assist Module																																																										
K	2011	Avalanche	Body	Passenger Door Switch																																																										
K	2011	Avalanche	Body	Passenger Presence System																																																										
K	2011	Avalanche	Body	Radio																																																										
K	2011	Avalanche	Body	Rear Heated Seat Module																																																										
K	2011	Avalanche	Body	Rear HVAC/RSA																																																										
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																									V	V																																
K	2011	Avalanche	Body	Theft Deterrent Module																																																										
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																												
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																												
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Cheyenne	Body	Amplifier (Bose)																																																												
K	2011	Cheyenne	Body	Body Control Module																																																												
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																												
K	2011	Cheyenne	Body	Digital Radio Receiver																																																												
K	2011	Cheyenne	Body	Driver Door Switch																																																												
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																												
K	2011	Cheyenne	Body	Park Assist Module																																																												
K	2011	Cheyenne	Body	Passenger Door Switch																																																												
K	2011	Cheyenne	Body	Passenger Presence System																																																												
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																												
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																												
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																									V	V																																	
K	2011	Cheyenne	Body	Theft Deterrent Module																																																												
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																												
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2011	Suburban	Chassis	Electronic Suspension Control																																																												
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Suburban	Body	Amplifier (Bose)																																																												
K	2011	Suburban	Body	Assist Step Controller																																																												
K	2011	Suburban	Body	Body Control Module																																																												
K	2011	Suburban	Body	Body Control Module (aux.)																																																												
K	2011	Suburban	Body	Digital Radio Receiver																																																												
K	2011	Suburban	Body	Driver Door Switch																																																												
K	2011	Suburban	Body	HVAC Control Module Auto																																												V															
K	2011	Suburban	Body	HVAC Control Module Manual																																												V															

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2011	Suburban	Body	Instrument Panel Cluster																																																												
K	2011	Suburban	Body	Left Side Object Detection Module																																																												
K	2011	Suburban	Body	Lift Gate Module																																																												
K	2011	Suburban	Body	Memory Seat Module																																																												
K	2011	Suburban	Body	Park Assist Module																																																												
K	2011	Suburban	Body	Passenger Door Switch																																																												
K	2011	Suburban	Body	Passenger Presence System																																																												
K	2011	Suburban	Body	Radio																																																												
K	2011	Suburban	Body	Rear Heated Seat Module																																																												
K	2011	Suburban	Body	Rear HVAC/RSA																																																												
K	2011	Suburban	Body	Right Side Object Detection Module																																																												
K	2011	Suburban	Body	Supplemental Inflatable Restraint																									V	V																																		
K	2011	Suburban	Body	Theft Deterrent Module																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
K	2011	Silverado	Chassis	Electronic Suspension Control																																																										
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2011	Silverado	Body	Amplifier (Bose)																																																										
K	2011	Silverado	Body	Body Control Module																																																										
K	2011	Silverado	Body	Body Control Module (aux.)																																																										
K	2011	Silverado	Body	Digital Radio Receiver																																																										
K	2011	Silverado	Body	Driver Door Switch																																																										
K	2011	Silverado	Body	HVAC Control Module Auto																																												V														
K	2011	Silverado	Body	HVAC Control Module Manual																																												V														
K	2011	Silverado	Body	Instrument Panel Cluster																																																										
K	2011	Silverado	Body	Memory Seat Module																																																										
K	2011	Silverado	Body	Park Assist Module																																																										
K	2011	Silverado	Body	Passenger Door Switch																																																										
K	2011	Silverado	Body	Passenger Presence System																																																										
K	2011	Silverado	Body	Radio																																																										
K	2011	Silverado	Body	Rear Heated Seat Module																																																										
K	2011	Silverado	Body	Rear HVAC/RSA																																																										
K	2011	Silverado	Body	Supplemental Inflatable Restraint																									V	V																																
K	2011	Silverado	Body	Theft Deterrent Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2011	Silverado Hybrid	Body	Body Control Module																																																										
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2011	Silverado Hybrid	Body	HVAC Control Module																																												V														
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2011	Silverado Hybrid	Body	Park Assist Module																																																										
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2011	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2011	Silverado Hybrid	Body	Radio																																																										
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2011	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Tahoe	Body	Amplifier (Bose)																																																										
K	2011	Tahoe	Body	Assist Step Controller																																																										
K	2011	Tahoe	Body	Body Control Module																																																										
K	2011	Tahoe	Body	Body Control Module (aux.)																																																										
K	2011	Tahoe	Body	Digital Radio Receiver																																																										
K	2011	Tahoe	Body	Driver Door Switch																																																										
K	2011	Tahoe	Body	HVAC Control Module Auto																																																										
K	2011	Tahoe	Body	HVAC Control Module Manual																																																										
K	2011	Tahoe	Body	Instrument Panel Cluster																																																										
K	2011	Tahoe	Body	Left Side Object Detection Module																																																										
K	2011	Tahoe	Body	Lift Gate Module																																																										
K	2011	Tahoe	Body	Memory Seat Module																																																										
K	2011	Tahoe	Body	Park Assist Module																																																										
K	2011	Tahoe	Body	Passenger Door Switch																																																										
K	2011	Tahoe	Body	Passenger Presence System																																																										
K	2011	Tahoe	Body	Radio																																																										
K	2011	Tahoe	Body	Rear Heated Seat Module																																																										
K	2011	Tahoe	Body	Rear HVAC/RSA																																																										
K	2011	Tahoe	Body	Right Side Object Detection Module																																																										
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																									V	V																																
K	2011	Tahoe	Body	Theft Deterrent Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2011	Tahoe Hybrid	Body	Body Control Module																																																										
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2011	Tahoe Hybrid	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2011	Tahoe Hybrid	Body	Radio																																																										
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2012	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Avalanche	Body	Amplifier (Bose)																																																										
K	2012	Avalanche	Body	Assist Step Controller																																																										
K	2012	Avalanche	Body	Body Control Module																																																										
K	2012	Avalanche	Body	Body Control Module (aux.)																																																										
K	2012	Avalanche	Body	Digital Radio Receiver																																																										
K	2012	Avalanche	Body	Driver Door Switch																																																										
K	2012	Avalanche	Body	HVAC Control Module Auto																																												V															
K	2012	Avalanche	Body	HVAC Control Module Manual																																												V															
K	2012	Avalanche	Body	Instrument Panel Cluster																																																										
K	2012	Avalanche	Body	Memory Seat Module																																																										
K	2012	Avalanche	Body	Navigation Radio																																																										
K	2012	Avalanche	Body	Park Assist Module																																																										
K	2012	Avalanche	Body	Passenger Door Switch																																																										
K	2012	Avalanche	Body	Passenger Presence System																																																										
K	2012	Avalanche	Body	Radio																																																										
K	2012	Avalanche	Body	Rear Heated Seat Module																																																										
K	2012	Avalanche	Body	Rear HVAC/RSA																																																										
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																									V	V																																
K	2012	Avalanche	Body	Theft Deterrent Module																																																										
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																									
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																									
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Cheyenne	Body	Amplifier (Bose)																																																									
K	2012	Cheyenne	Body	Body Control Module																																																									
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																									
K	2012	Cheyenne	Body	Digital Radio Receiver																																																									
K	2012	Cheyenne	Body	Driver Door Switch																																																									
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																									
K	2012	Cheyenne	Body	Park Assist Module																																																									
K	2012	Cheyenne	Body	Passenger Door Switch																																																									
K	2012	Cheyenne	Body	Passenger Presence System																																																									
K	2012	Cheyenne	Body	Rear Heated Seat Module																																																									
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																									
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																									V	V																															
K	2012	Cheyenne	Body	Theft Deterrent Module																																																									
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																									
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																									
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																									
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																									
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																									
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
K	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																									
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2012	Suburban	Chassis	Electronic Suspension Control																																																									
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Suburban	Body	Amplifier (Bose)																																																									
K	2012	Suburban	Body	Assist Step Controller																																																									
K	2012	Suburban	Body	Body Control Module																																																									
K	2012	Suburban	Body	Body Control Module (aux.)																																																									
K	2012	Suburban	Body	Digital Radio Receiver																																																									
K	2012	Suburban	Body	Driver Door Switch																																																									
K	2012	Suburban	Body	HVAC Control Module Auto																																											V														
K	2012	Suburban	Body	HVAC Control Module Manual																																											V														
K	2012	Suburban	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2012	Suburban	Body	Left Side Object Detection Module																																																									
K	2012	Suburban	Body	Lift Gate Module																																																										
K	2012	Suburban	Body	Memory Seat Module																																																										
K	2012	Suburban	Body	Navigation Radio																																																										
K	2012	Suburban	Body	Park Assist Module																																																										
K	2012	Suburban	Body	Passenger Door Switch																																																										
K	2012	Suburban	Body	Passenger Presence System																																																										
K	2012	Suburban	Body	Radio																																																										
K	2012	Suburban	Body	Rear Heated Seat Module																																																										
K	2012	Suburban	Body	Rear HVAC/RSA																																																										
K	2012	Suburban	Body	Right Side Object Detection Module																																																										
K	2012	Suburban	Body	Supplemental Inflatable Restraint																									V	V																																
K	2012	Suburban	Body	Theft Deterrent Module																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2012	Silverado	Chassis	Electronic Suspension Control																																																									
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2012	Silverado	Body	Amplifier (Bose)																																																										
K	2012	Silverado	Body	Body Control Module																																																										
K	2012	Silverado	Body	Body Control Module (aux.)																																																										
K	2012	Silverado	Body	Digital Radio Receiver																																																										
K	2012	Silverado	Body	Driver Door Switch																																																										
K	2012	Silverado	Body	HVAC Control Module Auto																																												V														
K	2012	Silverado	Body	HVAC Control Module Manual																																												V														
K	2012	Silverado	Body	Instrument Panel Cluster																																																										
K	2012	Silverado	Body	Memory Seat Module																																																										
K	2012	Silverado	Body	Navigation Radio																																																										
K	2012	Silverado	Body	Park Assist Module																																																										
K	2012	Silverado	Body	Passenger Door Switch																																																										
K	2012	Silverado	Body	Passenger Presence System																																																										
K	2012	Silverado	Body	Radio																																																										
K	2012	Silverado	Body	Rear Heated Seat Module																																																										
K	2012	Silverado	Body	Rear HVAC/RSA																																																										
K	2012	Silverado	Body	Supplemental Inflatable Restraint																									V	V																																
K	2012	Silverado	Body	Theft Deterrent Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2012	Silverado Hybrid	Body	Body Control Module																																																										
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2012	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2012	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2012	Silverado Hybrid	Body	HVAC Control Module																																												V														
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2012	Silverado Hybrid	Body	Navigation Radio																																																										
K	2012	Silverado Hybrid	Body	Park Assist Module																																																										
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2012	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2012	Silverado Hybrid	Body	Radio																																																										
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																												
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																													
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																													
K	2012	Tahoe	Chassis	EBCM with Trailer Brake																																																													
K	2012	Tahoe	Chassis	Electronic Suspension Control																																																													
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																													
K	2012	Tahoe	Body	Amplifier (Bose)																																																													
K	2012	Tahoe	Body	Assist Step Controller																																																													
K	2012	Tahoe	Body	Body Control Module																																																													
K	2012	Tahoe	Body	Body Control Module (aux.)																																																													
K	2012	Tahoe	Body	Digital Radio Receiver																																																													
K	2012	Tahoe	Body	Driver Door Switch																																																													
K	2012	Tahoe	Body	HVAC Control Module Auto																																												V																
K	2012	Tahoe	Body	HVAC Control Module Manual																																												V																
K	2012	Tahoe	Body	Instrument Panel Cluster																																																													
K	2012	Tahoe	Body	Left Side Object Detection Module																																																													
K	2012	Tahoe	Body	Lift Gate Module																																																													
K	2012	Tahoe	Body	Memory Seat Module																																																													
K	2012	Tahoe	Body	Navigation Radio																																																													
K	2012	Tahoe	Body	Park Assist Module																																																													
K	2012	Tahoe	Body	Passenger Door Switch																																																													
K	2012	Tahoe	Body	Passenger Presence System																																																													
K	2012	Tahoe	Body	Radio																																																													
K	2012	Tahoe	Body	Rear Heated Seat Module																																																													
K	2012	Tahoe	Body	Rear HVAC/RSA																																																													
K	2012	Tahoe	Body	Right Side Object Detection Module																																																													
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																									V	V																																		
K	2012	Tahoe	Body	Theft Deterrent Module																																																													
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																													
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																													
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																													
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																													
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																													
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																													
K	2012	Tahoe Hybrid	Body	Body Control Module																																																													
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																													
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																													
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																																													
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																																													

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2012	Tahoe Hybrid	Body	HVAC Control Module																																												V											
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																						
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																						
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																																						
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																						
K	2012	Tahoe Hybrid	Body	Park Assist Module																																																						
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																						
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																																						
K	2012	Tahoe Hybrid	Body	Radio																																																						
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																						
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																						
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																						
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																						
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																									V	V																												
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																						
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																						
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																						
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																						
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																						
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																						
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																						
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																						
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																						
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																						
K	2013	Avalanche	Chassis	Electronic Brake Control Module																																																						
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																						
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																						
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																						
K	2013	Avalanche	Body	Amplifier (Bose)																																																						
K	2013	Avalanche	Body	Assist Step Controller																																																					
K	2013	Avalanche	Body	Body Control Module																																																					
K	2013	Avalanche	Body	Body Control Module (aux.)																																																					
K	2013	Avalanche	Body	Digital Radio Receiver																																																					
K	2013	Avalanche	Body	Driver Door Switch																																																					
K	2013	Avalanche	Body	HVAC Control Module Auto																																												V											
K	2013	Avalanche	Body	HVAC Control Module Manual																																												V											
K	2013	Avalanche	Body	Instrument Panel Cluster																																																						
K	2013	Avalanche	Body	Memory Seat Module																																																					
K	2013	Avalanche	Body	Navigation Radio																																																					
K	2013	Avalanche	Body	Park Assist Module																																																					
K	2013	Avalanche	Body	Passenger Door Switch																																																					
K	2013	Avalanche	Body	Passenger Presence System																																																					
K	2013	Avalanche	Body	Radio																																																					
K	2013	Avalanche	Body	Rear Heated Seat Module																																																					
K	2013	Avalanche	Body	Rear HVAC/RSA																																																					
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																									V	V																												
K	2013	Avalanche	Body	Theft Deterrent Module																																																					
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																					
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																					
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																												
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Cheyenne	Body	Amplifier (Bose)																																																												
K	2013	Cheyenne	Body	Body Control Module																																																												
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																												
K	2013	Cheyenne	Body	Digital Radio Receiver																																																												
K	2013	Cheyenne	Body	Driver Door Switch																																																												
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																												
K	2013	Cheyenne	Body	Park Assist Module																																																												
K	2013	Cheyenne	Body	Passenger Door Switch																																																												
K	2013	Cheyenne	Body	Passenger Presence System																																																												
K	2013	Cheyenne	Body	Rear Heated Seat Module																																																												
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																												
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																									V	V																																	
K	2013	Cheyenne	Body	Theft Deterrent Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																												
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																												
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2013	Suburban	Chassis	Electronic Suspension Control																																																												
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Suburban	Body	Amplifier (Bose)																																																												
K	2013	Suburban	Body	Assist Step Controller																																																												
K	2013	Suburban	Body	Body Control Module																																																												
K	2013	Suburban	Body	Body Control Module (aux.)																																																												
K	2013	Suburban	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2013	Suburban	Body	Driver Door Switch																																																								
K	2013	Suburban	Body	HVAC Control Module Auto																																												V												
K	2013	Suburban	Body	HVAC Control Module Manual																																												V												
K	2013	Suburban	Body	Instrument Panel Cluster																																																								
K	2013	Suburban	Body	Left Side Object Detection Module																																																								
K	2013	Suburban	Body	Lift Gate Module																																																								
K	2013	Suburban	Body	Memory Seat Module																																																								
K	2013	Suburban	Body	Navigation Radio																																																								
K	2013	Suburban	Body	Park Assist Module																																																								
K	2013	Suburban	Body	Passenger Door Switch																																																								
K	2013	Suburban	Body	Passenger Presence System																																																								
K	2013	Suburban	Body	Radio																																																								
K	2013	Suburban	Body	Rear Heated Seat Module																																																								
K	2013	Suburban	Body	Rear HVAC/RSA																																																								
K	2013	Suburban	Body	Right Side Object Detection Module																																																								
K	2013	Suburban	Body	Supplemental Inflatable Restraint																									V	V																															
K	2013	Suburban	Body	Theft Deterrent Module																																																								
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																								
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																								
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																								
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																								
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																								
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																								
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																								
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																								
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																								
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
K	2013	Silverado	Chassis	Electronic Suspension Control																																																								
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
K	2013	Silverado	Body	Amplifier (Bose)																																																								
K	2013	Silverado	Body	Body Control Module																																																								
K	2013	Silverado	Body	Body Control Module (aux.)																																																								
K	2013	Silverado	Body	Digital Radio Receiver																																																								
K	2013	Silverado	Body	Driver Door Switch																																																								
K	2013	Silverado	Body	HVAC Control Module Auto																																														V										
K	2013	Silverado	Body	HVAC Control Module Manual																																														V										
K	2013	Silverado	Body	Instrument Panel Cluster																																																								
K	2013	Silverado	Body	Memory Seat Module																																																								
K	2013	Silverado	Body	Navigation Radio																																																								
K	2013	Silverado	Body	Park Assist Module																																																								
K	2013	Silverado	Body	Passenger Door Switch																																																								
K	2013	Silverado	Body	Passenger Presence System																																																								
K	2013	Silverado	Body	Radio																																																								
K	2013	Silverado	Body	Rear Heated Seat Module																																																								
K	2013	Silverado	Body	Rear HVAC/RSA																																																								
K	2013	Silverado	Body	Supplemental Inflatable Restraint																									V	V																														
K	2013	Silverado	Body	Theft Deterrent Module																																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																								
K	2013	Silverado Hybrid	Body	Body Control Module																																																								
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																								
K	2013	Silverado Hybrid	Body	Driver Door Switch																																																								
K	2013	Silverado Hybrid	Body	Heated Seat Module																																																								
K	2013	Silverado Hybrid	Body	HVAC Control Module																																														V										
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
K	2013	Silverado Hybrid	Body	Navigation Radio																																																								
K	2013	Silverado Hybrid	Body	Park Assist Module																																																								
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																																								
K	2013	Silverado Hybrid	Body	Passenger Presence System																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2013	Silverado Hybrid	Body	Radio																																																								
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																									V	V																														
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2013	Tahoe	Chassis	Electronic Brake Control Module																																																								
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																								
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Tahoe	Body	Amplifier (Bose)																																																								
K	2013	Tahoe	Body	Assist Step Controller																																																								
K	2013	Tahoe	Body	Body Control Module																																																								
K	2013	Tahoe	Body	Body Control Module (aux.)																																																								
K	2013	Tahoe	Body	Digital Radio Receiver																																																								
K	2013	Tahoe	Body	Driver Door Switch																																																								
K	2013	Tahoe	Body	HVAC Control Module Auto																																													V											
K	2013	Tahoe	Body	HVAC Control Module Manual																																													V											
K	2013	Tahoe	Body	Instrument Panel Cluster																																																								
K	2013	Tahoe	Body	Left Side Object Detection Module																																																								
K	2013	Tahoe	Body	Lift Gate Module																																																								
K	2013	Tahoe	Body	Memory Seat Module																																																								
K	2013	Tahoe	Body	Navigation Radio																																																								
K	2013	Tahoe	Body	Park Assist Module																																																								
K	2013	Tahoe	Body	Passenger Door Switch																																																								
K	2013	Tahoe	Body	Passenger Presence System																																																								
K	2013	Tahoe	Body	Radio																																																								
K	2013	Tahoe	Body	Rear Heated Seat Module																																																								
K	2013	Tahoe	Body	Rear HVAC/RSA																																																								
K	2013	Tahoe	Body	Right Side Object Detection Module																																																								
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																									V	V																														
K	2013	Tahoe	Body	Theft Deterrent Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
K	2013	Tahoe Hybrid	Body	Body Control Module																																																								
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																								
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																								
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																																								
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																																								
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																								
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																								
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																								
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																																								
K	2013	Tahoe Hybrid	Body	Radio																																																								
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																									V	V																														
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																				
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																				
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																		
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control						V																																																		
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2014	Cheyenne	Chassis	Electronic Brake Control Module					V																																																			
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																								
K	2014	Cheyenne	Chassis	Power Steering Control Module																																																								
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
K	2014	Cheyenne	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V	V		V	V																								V								
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
K	2014	Cheyenne	Body	Passenger Presence Module																															V																									
K	2014	Cheyenne	Body	Instrument Cluster																																V																								
K	2014	Cheyenne	Body	Radio Control																																																								
K	2014	Cheyenne	Body	HVAC Control																																																								
K	2014	Cheyenne	Body	Radio																																																								
K	2014	Cheyenne	Body	Amplifier																																																								
K	2014	Cheyenne	Body	Media Disc Player																																																								
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																								
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																V	V	V	V																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2014	Cheyenne	Body	HVAC Control Module																															V												V	V	V		V								
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																								V	V												
K	2014	Cheyenne	Body	Parking Assist Control Module																																V																					
K	2014	Cheyenne	Body	Frontview Camera Module																																																				
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																	
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																	
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																				
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																	
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																				
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																	
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																				
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																				
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																				
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																														
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control						V																																														
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																				
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																				
K	2014	Silverado	Chassis	Electronic Brake Control Module					V																																														
K	2014	Silverado	Chassis	Parking Brake Control Module																																																			
K	2014	Silverado	Chassis	Power Steering Control Module																																																			
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module				V	V																																														
K	2014	Silverado	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V	V		V	V																							V					
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																					
K	2014	Silverado	Body	Passenger Presence Module																																V																					
K	2014	Silverado	Body	Instrument Cluster																																	V																				
K	2014	Silverado	Body	Radio Control																																																				
K	2014	Silverado	Body	HVAC Control																																																				
K	2014	Silverado	Body	Radio																																																				
K	2014	Silverado	Body	Amplifier																																																				
K	2014	Silverado	Body	Media Disc Player																																																				
K	2014	Silverado	Body	Human Machine Interface Control Module																																																				
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																	
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																		
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																															V											V	V	V		V								
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																															V											V	V	V		V								
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																															V											V	V	V		V								
K	2014	Silverado	Body	Parking Assist Control Module																																	V																				
K	2014	Silverado	Body	Frontview Camera Module																																																				
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																				
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																	
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																				
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																	
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																				
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																				
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																				
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																				
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																				
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																				
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																				
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																				
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2014	Silverado HD	Chassis	Suspension Control Module																																																								
K	2014	Silverado HD	Body	Body Control Module						V	V	V						V				V	V	V																																				
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
K	2014	Silverado HD	Body	Passenger Presence Module																										V																														
K	2014	Silverado HD	Body	Instrument Cluster																																																								
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																								
K	2014	Silverado HD	Body	Base Radio																																																								
K	2014	Silverado HD	Body	Navigation Radio																																																								
K	2014	Silverado HD	Body	Uplevel Radio																																																								
K	2014	Silverado HD	Body	Amplifier																																																								
K	2014	Silverado HD	Body	Rear Audio Control Module																																																								
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																								
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																								
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																										V	V			V										
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																										V	V			V										
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																										V	V			V										
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																										V	V			V										
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																	V																																							
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																								
K	2014	Silverado HD	Body	Seat Memory Control Module																																					V	V																		
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																								
K	2014	Silverado HD	Body	Parking Assist Control Module																																																								
K	2014	Silverado HD	Body	Theft Deterrent Module										V																																														
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																								
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																								
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump						V																																																		
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																								
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																								
K	2014	Suburban	Chassis	Parking Brake Control Module																																																								
K	2014	Suburban	Chassis	Suspension Control Module																																																								
K	2014	Suburban	Body	Body Control Module						V	V	V						V				V	V	V																																				
K	2014	Suburban	Body	Auxiliary Body Control Module																																																								
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
K	2014	Suburban	Body	Passenger Presence Module																										V																														
K	2014	Suburban	Body	Instrument Cluster																																																								
K	2014	Suburban	Body	Base Radio																																																								
K	2014	Suburban	Body	Navigation Radio																																																								
K	2014	Suburban	Body	Uplevel Radio																																																								
K	2014	Suburban	Body	Amplifier																																																								
K	2014	Suburban	Body	Rear Audio Control Module																																																								
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																								
K	2014	Suburban	Body	Personal Audio Link Control Module																																																								
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																											V	V			V								
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																											V	V			V								
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																	V																																							
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																								
K	2014	Suburban	Body	Liftgate Control Module																																																								
K	2014	Suburban	Body	Seat Memory Control Module																																					V	V																		
K	2014	Suburban	Body	Rear Seat Heating Control Module																																							V	V															
K	2014	Suburban	Body	Assist Step Control Module																																																								
K	2014	Suburban	Body	Right Side Object Detection Control Module																																									V	V													
K	2014	Suburban	Body	Left Side Object Detection Control Module																																									V	V													
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																								
K	2014	Suburban	Body	Parking Assist Control Module																																																								
K	2014	Suburban	Body	Theft Deterrent Module										V																																														
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump						V																																																	
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																								
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																								
K	2014	Tahoe	Chassis	Suspension Control Module																																																								
K	2014	Tahoe	Body	Body Control Module						V	V	V						V				V	V	V																																				
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																								
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
K	2014	Tahoe	Body	Passenger Presence Module																										V																														
K	2014	Tahoe	Body	Instrument Cluster																																																								
K	2014	Tahoe	Body	Base Radio																																																								
K	2014	Tahoe	Body	Navigation Radio																																																								
K	2014	Tahoe	Body	Uplevel Radio																																																								
K	2014	Tahoe	Body	Amplifier																																																								
K	2014	Tahoe	Body	Rear Audio Control Module																																																								
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																								
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																								
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																				
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																				
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																											V	V			V								
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																											V	V			V								
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																	V																																							
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																								
K	2014	Tahoe	Body	Liftgate Control Module																																																								
K	2014	Tahoe	Body	Seat Memory Control Module																																					V	V																		
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																							V	V															
K	2014	Tahoe	Body	Assist Step Control Module																																																								
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																									V	V													
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																									V	V													
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																								
K	2014	Tahoe	Body	Parking Assist Control Module																																																								
K	2014	Tahoe	Body	Theft Deterrent Module										V																																														
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																				
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																								
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																	
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control						V																																																	
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2015	Cheyenne	Chassis	Electronic Brake Control Module					V																																																			
K	2015	Cheyenne	Chassis	Power Steering Control Module																																																								
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
K	2015	Cheyenne	Chassis	Suspension Control Module																																																								
K	2015	Cheyenne	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																								V						
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
K	2015	Cheyenne	Body	Passenger Presence Module																																V																							
K	2015	Cheyenne	Body	Instrument Cluster																																	V																					
K	2015	Cheyenne	Body	Radio Controls																																																							
K	2015	Cheyenne	Body	HVAC Controls																																																							
K	2015	Cheyenne	Body	Radio																																																							
K	2015	Cheyenne	Body	Amplifier																																																							
K	2015	Cheyenne	Body	Media Disc Player																																																							
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																							
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																	V	V	V	V																		
K	2015	Cheyenne	Body	HVAC Control Module																														V													V	V	V		V						
K	2015	Cheyenne	Body	Parking Assist Control Module																																V																							
K	2015	Cheyenne	Body	Frontview Camera Module																																																							
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																				
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																				
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																								
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																								
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																								
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																		
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control						V																																																		
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																								
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																							
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																							
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																							
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																							
K	2015	Silverado	Chassis	Electronic Brake Control Module					V																																																		
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																							
K	2015	Silverado	Chassis	Power Steering Control Module																																																							
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
K	2015	Silverado	Chassis	Suspension Control Module																																																							
K	2015	Silverado	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																								V						
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
K	2015	Silverado	Body	Passenger Presence Module																																V																						
K	2015	Silverado	Body	Instrument Cluster																																	V																				
K	2015	Silverado	Body	Radio Controls																																																						
K	2015	Silverado	Body	HVAC Controls																																																					
K	2015	Silverado	Body	Radio																																																					
K	2015	Silverado	Body	Amplifier																																																				
K	2015	Silverado	Body	Media Disc Player																																																				
K	2015	Silverado	Body	Human Machine Interface Control Module																																																				
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																	V	V	V	V																
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V	V		V						
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																														V												V	V	V		V						
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																														V												V	V	V		V						
K	2015	Silverado	Body	Parking Assist Control Module																																V																				
K	2015	Silverado	Body	Frontview Camera Module																																																				
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																	
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																				
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																				
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																															
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control						V																																															
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																				
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																				
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																				
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																				
K	2015	Suburban	Chassis	Electronic Brake Control Module					V																																															
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																				
K	2015	Suburban	Chassis	Parking Brake Control Module																																																				
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																				
K	2015	Suburban	Chassis	Power Steering Control Module																																																				
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module				V	V																																																
K	2015	Suburban	Chassis	Suspension Control Module																																																				
K	2015	Suburban	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V						
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																						
K	2015	Suburban	Body	Passenger Presence Module																																V																				
K	2015	Suburban	Body	Instrument Cluster																																	V																			
K	2015	Suburban	Body	Radio Controls																																																				
K	2015	Suburban	Body	HVAC Controls																																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2015	Suburban	Body	Radio																																																								
K	2015	Suburban	Body	Amplifier																																																								
K	2015	Suburban	Body	Media Disc Player																																																								
K	2015	Suburban	Body	Human Machine Interface Control Module																																																								
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																	V	V	V	V																				
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
K	2015	Suburban	Body	HVAC Control Module																														V														V	V	V		V								
K	2015	Suburban	Body	Liftgate Control Module																																																								
K	2015	Suburban	Body	Keyless Entry Control Module																																																								
K	2015	Suburban	Body	Assist Step Control Module																																																								
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																								
K	2015	Suburban	Body	Parking Assist Control Module																																V																								
K	2015	Suburban	Body	Frontview Camera Module																																																								
K	2015	Suburban	Body	Steering Column Lock Control Module																																																								
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																		
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control						V																																																		
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																								
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																								
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																								
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																								
K	2015	Tahoe	Chassis	Electronic Brake Control Module				V																																																				
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																								
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																								
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2015	Tahoe	Chassis	Power Steering Control Module																																																								
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
K	2015	Tahoe	Chassis	Suspension Control Module																																																								
K	2015	Tahoe	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																										V						
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																								
K	2015	Tahoe	Body	Passenger Presence Module																															V																									
K	2015	Tahoe	Body	Instrument Cluster																																V																								
K	2015	Tahoe	Body	Radio Controls																																																								
K	2015	Tahoe	Body	HVAC Controls																																																								
K	2015	Tahoe	Body	Radio																																																								
K	2015	Tahoe	Body	Amplifier																																																								
K	2015	Tahoe	Body	Media Disc Player																																																								
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																								
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																	V	V	V	V																				
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
K	2015	Tahoe	Body	HVAC Control Module																														V														V	V	V		V								
K	2015	Tahoe	Body	Liftgate Control Module																																																								
K	2015	Tahoe	Body	Keyless Entry Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2015	Tahoe	Body	Assist Step Control Module																																																								
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																								
K	2015	Tahoe	Body	Parking Assist Control Module																																V																								
K	2015	Tahoe	Body	Frontview Camera Module																																																								
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																								
K	2015	Tahoe	Body	Battery Energy Control Module																																																								
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																								
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																								
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2016	Cheyenne	Chassis	Electronic Brake Control Module					V																																																			
K	2016	Cheyenne	Chassis	Power Steering Control Module																																																								
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
K	2016	Cheyenne	Chassis	Suspension Control Module																																																								
K	2016	Cheyenne	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V							
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
K	2016	Cheyenne	Body	Passenger Presence Module																															V																									
K	2016	Cheyenne	Body	Instrument Cluster																																V																								
K	2016	Cheyenne	Body	Radio Controls																																																								
K	2016	Cheyenne	Body	HVAC Controls																																																								
K	2016	Cheyenne	Body	Radio																																																								
K	2016	Cheyenne	Body	Amplifier																																																								
K	2016	Cheyenne	Body	Media Disc Player																																																								
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																								
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																	V	V	V																					
K	2016	Cheyenne	Body	HVAC Control Module																														V													V	V	V		V									
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																								
K	2016	Cheyenne	Body	Parking Assist Control Module																																V																								
K	2016	Cheyenne	Body	Frontview Camera Module																																																								
K	2016	Cheyenne	Body	Frontview Camera Module																																																								
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																				
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																				
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																								
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																								
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																				V																																				
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																								
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																						V	V
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																								
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																								
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																								
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																								
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2016	Silverado	Chassis	Electronic Brake Control Module					V																																																			
K	2016	Silverado	Chassis	Power Steering Control Module																																																			V					
K	2016	Silverado	Chassis	Power Steering Control Module																																																								
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
K	2016	Silverado	Chassis	Suspension Control Module																																																								
K	2016	Silverado	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V							
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
K	2016	Silverado	Body	Passenger Presence Module																																V																								
K	2016	Silverado	Body	Instrument Cluster																																	V																							
K	2016	Silverado	Body	Radio Controls																																																								
K	2016	Silverado	Body	HVAC Controls																																																								
K	2016	Silverado	Body	Radio (IO3)																																																								
K	2016	Silverado	Body	Radio (IOB)																																																								
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																								
K	2016	Silverado	Body	Amplifier																																																								
K	2016	Silverado	Body	Media Disc Player																																																								
K	2016	Silverado	Body	Human Machine Interface Control Module																																																								
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																															V												V	V	V		V									
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																															V												V	V	V		V									
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																															V												V	V	V		V									
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																								
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																								
K	2016	Silverado	Body	Parking Assist Control Module																																	V																							
K	2016	Silverado	Body	Frontview Camera Module																																																								
K	2016	Silverado	Body	Frontview Camera Module																																																								
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2016	Suburban	Chassis	Electronic Brake Control Module					V																																																			
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																								
K	2016	Suburban	Chassis	Parking Brake Control Module																																																								
K	2016	Suburban	Chassis	Power Steering Control Module																																																								
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
K	2016	Suburban	Chassis	Suspension Control Module																																																								
K	2016	Suburban	Body	Body Control Module						V	V	V		V	V		V	V	V		V	V	V	V	V	V	V	V																									V							
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2016	Suburban	Body	Passenger Presence Module																																V																								
K	2016	Suburban	Body	Instrument Cluster																																	V																						
K	2016	Suburban	Body	Radio Controls																																																							
K	2016	Suburban	Body	HVAC Controls																																																							
K	2016	Suburban	Body	Radio																																																							
K	2016	Suburban	Body	Amplifier																																																							
K	2016	Suburban	Body	Media Disc Player																																																							
K	2016	Suburban	Body	Human Machine Interface Control Module																																																							
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																	V	V	V																					
K	2016	Suburban	Body	HVAC Control Module																														V												V	V	V		V									
K	2016	Suburban	Body	Liftgate Control Module																																																							
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																							
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																							
K	2016	Suburban	Body	Keyless Entry Control Module																																																							
K	2016	Suburban	Body	Assist Step Control Module																																																							
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																							
K	2016	Suburban	Body	Parking Assist Control Module																																	V																						
K	2016	Suburban	Body	Frontview Camera Module																																																							
K	2016	Suburban	Body	Steering Column Lock Control Module																																																							
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																							
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																							
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																							
K	2016	Tahoe	Chassis	Electronic Brake Control Module					V																																																		
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																							
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																							
K	2016	Tahoe	Chassis	Power Steering Control Module																																																							
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
K	2016	Tahoe	Chassis	Suspension Control Module																																																							
K	2016	Tahoe	Body	Body Control Module						V	V	V		V	V		V	V	V		V	V	V	V	V	V	V	V																								V						
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
K	2016	Tahoe	Body	Passenger Presence Module																																V																								
K	2016	Tahoe	Body	Instrument Cluster																																	V																						
K	2016	Tahoe	Body	Radio Controls																																																						
K	2016	Tahoe	Body	HVAC Controls																																																						
K	2016	Tahoe	Body	Radio																																																						
K	2016	Tahoe	Body	Amplifier																																																						
K	2016	Tahoe	Body	Media Disc Player																																																						
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																						
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																	V	V	V																					
K	2016	Tahoe	Body	HVAC Control Module																														V												V	V	V		V									
K	2016	Tahoe	Body	Liftgate Control Module																																																						
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																						
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																						
K	2016	Tahoe	Body	Keyless Entry Control Module																																																						
K	2016	Tahoe	Body	Assist Step Control Module																																																						
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																						
K	2016	Tahoe	Body	Parking Assist Control Module																																	V																						
K	2016	Tahoe	Body	Frontview Camera Module																																																						
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																						
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
L	2004	ALL	Chassis	4WAL 3 Sensor																																																									
L	2004	ALL	Body	Body Control Module																														V																											
L	2004	ALL	Body	Instrument Panel Cluster																																																								
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
L	2005	Astro	Chassis	4WAL 3 Sensor																																																								
L	2005	Astro	Body	Body Control Module																														V																										
L	2005	Astro	Body	Instrument Panel Cluster																																																								
L	2005	Astro	Body	Supplemental Inflatable Restraint																																																								
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																								
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																								
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																																								
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																																								
L	2005	Equinox	Chassis	Electric Power Steering																																																								
L	2005	Equinox	Body	Body Control Module																														V																										
L	2005	Equinox	Body	Instrument Panel Cluster																																																								
L	2005	Equinox	Body	Radio																																																								
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																																								
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																								
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																								
L	2006	ALL	Chassis	Traction Control Yes																																																								
L	2006	ALL	Chassis	Traction Control No																																																								
L	2006	ALL	Chassis	Electric Power Steering																																																								
L	2006	ALL	Body	Body Control Module																														V																										
L	2006	ALL	Body	Instrument Panel Cluster																																																								
L	2006	ALL	Body	Radio																																																								
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																								
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																								
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																								
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																																								
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																																								
L	2007	ALL	Chassis	Power Steering Control Module																																																								
L	2007	ALL	Body	Body Control Module																																																								
L	2007	ALL	Body	Digital Radio Receiver																																																								
L	2007	ALL	Body	Heated Seat Module																																																								
L	2007	ALL	Body	HVAC Control Module																																												V													
L	2007	ALL	Body	Instrument Panel Cluster																																																								
L	2007	ALL	Body	Passenger Presence System																																																								
L	2007	ALL	Body	Radio																																																								
L	2007	ALL	Body	Rollover Sensor																																																								
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2007	ALL	Body	Theft Deterrent Module																																																								
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																								
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																								
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2008	Captiva Sport	Body	Body Control Module																																																										
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2008	Captiva Sport	Body	HVAC Control Module Auto																																												V														
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																												V														
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2008	Captiva Sport	Body	Passenger Presence System																																																										
L	2008	Captiva Sport	Body	Radio																																																										
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2008	Captiva Sport	Body	Rollover Sensor																																																										
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2008	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2008	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2008	Equinox	Chassis	Power Steering Control Module																																																										
L	2008	Equinox	Body	Body Control Module																																																										
L	2008	Equinox	Body	Digital Radio Receiver																																																										
L	2008	Equinox	Body	Heated Seat Module																																																										
L	2008	Equinox	Body	HVAC Control Module																																												V														
L	2008	Equinox	Body	Instrument Panel Cluster																																																										
L	2008	Equinox	Body	Passenger Presence System																																																										
L	2008	Equinox	Body	Radio																																																										
L	2008	Equinox	Body	Rollover Sensor																																																										
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2008	Equinox	Body	Theft Deterrent Module																																																										
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																										
L	2009	Captiva Sport	Body	Body Control Module																																																										
L	2009	Captiva Sport	Body	HVAC Control Module Auto																																												V														
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																												V														
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2009	Captiva Sport	Body	Passenger Presence System																																																										
L	2009	Captiva Sport	Body	Radio																																																										
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2009	Captiva Sport	Body	Rollover Sensor																																																										
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2009	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																									
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2009	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2009	Equinox	Chassis	Power Steering Control Module																																																										
L	2009	Equinox	Body	Body Control Module																																																										
L	2009	Equinox	Body	Digital Radio Receiver																																																										
L	2009	Equinox	Body	Heated Seat Module																																																										
L	2009	Equinox	Body	HVAC Control Module																																											V															
L	2009	Equinox	Body	Instrument Panel Cluster																																																										
L	2009	Equinox	Body	Passenger Presence System																																																										
L	2009	Equinox	Body	Radio																																																										
L	2009	Equinox	Body	Rollover Sensor																																																										
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2009	Equinox	Body	Theft Deterrent Module																																																										
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																										
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																										
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																										
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																										
L	2010	Captiva Sport	Body	Body Control Module																																																										
L	2010	Captiva Sport	Body	HVAC Control Module																																											V															
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2010	Captiva Sport	Body	Passenger Presence System																																																										
L	2010	Captiva Sport	Body	Radio																																																										
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2010	Captiva Sport	Body	Rollover Sensor																																																										
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2010	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																										
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																										
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																										
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2010	Equinox	Chassis	Electronic Brake Control Module					V																																																				
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
L	2010	Equinox	Body	Body Control Module						V	V	V	V	V	V	V		V	V	V	V	V	V	V			V	V																																
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
L	2010	Equinox	Body	Passenger Presence Module																																V																								
L	2010	Equinox	Body	Instrument Cluster																																	V																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2010	Equinox	Body	Radio																																																								
L	2010	Equinox	Body	Multimedia Player Interface Module																																	V																							
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																															V												V	V	V	V	V									
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																															V												V	V	V	V	V									
L	2010	Equinox	Body	Liftgate Control Module																																																								
L	2010	Equinox	Body	Parking Assist Control Module																																	V																							
L	2010	Equinox	Body	Frontview Camera Module																																																								
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																																								
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																								
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																				V																																				
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																								
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																								
L	2011	Captiva	Chassis	Electronic Brake Control Module				V																																																				
L	2011	Captiva	Chassis	Parking Brake Control Module																																																								
L	2011	Captiva	Body	Body Control Module					V	V	V					V				V	V																										V													
L	2011	Captiva	Body	Auxiliary Body Control Module																																																								
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
L	2011	Captiva	Body	Instrument Cluster																																																								
L	2011	Captiva	Body	Headlamp Control Module																																																								
L	2011	Captiva	Body	HVAC Control Module																																																								
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																								
L	2011	Captiva	Body	Parking Assist Control Module																																																								
L	2011	Captiva	Body	Theft Deterrent Module										V																																														
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module																																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module																																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																				V																																				
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module																																																								
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																																								
L	2011	Captiva Sport	Body	Body Control Module																																																								
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																								
L	2011	Captiva Sport	Body	HVAC Control Module																																																								
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																																								
L	2011	Captiva Sport	Body	Passenger Presence System																																																								
L	2011	Captiva Sport	Body	Radio																																																								
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																																								
L	2011	Captiva Sport	Body	Rollover Sensor																																																								
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																									V	V																														
L	2011	Captiva Sport	Body	Theft Deterrent Module																																																								
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																				V																												V								
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																								
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																				
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																								
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																								
L	2011	Equinox	Chassis	Electronic Brake Control Module					V																																																			
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
L	2011	Equinox	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																											V					
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
L	2011	Equinox	Body	Passenger Presence Module																																V																								
L	2011	Equinox	Body	Instrument Cluster																																	V																							
L	2011	Equinox	Body	Radio																																																								
L	2011	Equinox	Body	Multimedia Player Interface Module																																V																								
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																														V													V	V	V	V	V									
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																														V													V	V	V	V	V									
L	2011	Equinox	Body	Liftgate Control Module																																																								
L	2011	Equinox	Body	Parking Assist Control Module																																V																								
L	2011	Equinox	Body	Frontview Camera Module																																																								
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																																																								
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																								
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																								
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																				V																																				
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																								
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																								
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																								
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																				
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																								
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																								
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																				V																																				
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																								
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																				
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																							
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																							
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																							
L	2012	Captiva	Chassis	Electronic Brake Control Module					V																																																		
L	2012	Captiva	Chassis	Parking Brake Control Module																																																							
L	2012	Captiva	Body	Body Control Module						V	V	V					V					V	V																								V												
L	2012	Captiva	Body	Auxiliary Body Control Module																																																							
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																										
L	2012	Captiva	Body	Instrument Cluster																																																						
L	2012	Captiva	Body	Headlamp Control Module																																																						
L	2012	Captiva	Body	HVAC Control Module																																																						
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																						
L	2012	Captiva	Body	Parking Assist Control Module																																																						
L	2012	Captiva	Body	Theft Deterrent Module										V																																												
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																				V																																			
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																						
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																						
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																						
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																				V																																			
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																						
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																						
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																						
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module																																																						
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																																						
L	2012	Captiva Sport	Body	Body Control Module																																																						
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																						
L	2012	Captiva Sport	Body	HVAC Control Module																																										V												
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																																						
L	2012	Captiva Sport	Body	Passenger Presence System																																																						
L	2012	Captiva Sport	Body	Radio																																																						
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																																						
L	2012	Captiva Sport	Body	Rollover Sensor																																																						
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																									V	V																													
L	2012	Captiva Sport	Body	Theft Deterrent Module																																																						
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																				V																											V								
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																						
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																			
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																						
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																						
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																						
L	2012	Equinox	Chassis	Electronic Brake Control Module					V																																																	
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																						
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
L	2012	Equinox	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																							V							
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
L	2012	Equinox	Body	Passenger Presence Module																																V																							
L	2012	Equinox	Body	Instrument Cluster																																	V																					
L	2012	Equinox	Body	Radio																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2012	Equinox	Body	Multimedia Player Interface Module																																V																								
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																			
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																														V											V	V	V	V	V										
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																														V											V	V	V	V	V										
L	2012	Equinox	Body	Liftgate Control Module																																																							
L	2012	Equinox	Body	Parking Assist Control Module																																V																							
L	2012	Equinox	Body	Frontview Camera Module																																																						
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																																						
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																						
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																						
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																						
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																						
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																						
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																						
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																				V																																			
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																						
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																						
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																			
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																						
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																						
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																						
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																			
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																						
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																						
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																						
L	2013	Captiva	Chassis	Electronic Brake Control Module					V																																																	
L	2013	Captiva	Chassis	Parking Brake Control Module																																																						
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto						V	V	V						V					V	V																																			
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual						V	V	V						V					V	V																							V											
L	2013	Captiva	Body	Auxiliary Body Control Module																																																						
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																								
L	2013	Captiva	Body	Instrument Cluster																																																					
L	2013	Captiva	Body	Headlamp Control Module																																																					
L	2013	Captiva	Body	HVAC Control Module																																																					
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																					
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)										V			V																																								
L	2013	Captiva	Body	Theft Deterrent Module										V																																											
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																				V																																			
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																						
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																						
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																				V																																			
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																						
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																						
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																																						
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																						
L	2013	Captiva Sport	Body	Body Control Module																																																						
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																						
L	2013	Captiva Sport	Body	Heated Seat Module																																																						
L	2013	Captiva Sport	Body	HVAC Control Module																																										V												
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2013	Captiva Sport	Body	Park Assist Module																																																									
L	2013	Captiva Sport	Body	Passenger Presence System																																																										
L	2013	Captiva Sport	Body	Radio																																																									
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																									
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																									V	V																															
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																									
L	2013	Captiva Sport	Body	Theft Deterrent Module																																																									
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																				V																												V							
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																								
L	2013	Equinox	Chassis	Electronic Brake Control Module					V																																																			
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2013	Equinox	Chassis	Power Steering Control Module	V	V	V																																																						
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																								V							
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																								V							
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
L	2013	Equinox	Body	Passenger Presence Module																																V																								
L	2013	Equinox	Body	Instrument Cluster																																	V																						
L	2013	Equinox	Body	Radio																																																								
L	2013	Equinox	Body	Rear Audio Control Module																																																								
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V							
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V							
L	2013	Equinox	Body	Liftgate Control Module																																																								
L	2013	Equinox	Body	Front Seat Heating Control Module																																						V	V																	
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																								
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																								
L	2013	Equinox	Body	Parking Assist Control Module																																	V																						
L	2013	Equinox	Body	Frontview Camera Module																																																								
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																				V																																				
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																				
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																								
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module					V																																																			
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																								
L	2014	Captiva (3GN)	Body	Body Control Module						V	V	V						V				V	V	V																								V											
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																									
L	2014	Captiva (3GN)	Body	Passenger Presence Module																										V																														
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																								
L	2014	Captiva (3GN)	Body	Radio																																																								
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																								
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																								
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
L	2014	Captiva (3GN)	Body	HVAC Control Module																																									V	V		V	V									
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																						V	V																

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2014	Captiva (3GN)	Body	Theft Deterrent Module										V																																															
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																									
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																									
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																				V																																					
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																									
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																									
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																					
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																									
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																					
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																									
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																									
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module					V																																																				
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																									
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto						V	V	V						V					V	V																																					
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual						V	V	V						V					V	V																									V												
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																									
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
L	2014	Captiva (Other)	Body	Instrument Cluster																																																									
L	2014	Captiva (Other)	Body	Headlamp Control Module																																																									
L	2014	Captiva (Other)	Body	HVAC Control Module																																																									
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																									
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)										V			V																																											
L	2014	Captiva (Other)	Body	Theft Deterrent Module										V																																															
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																				V																														V							
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																					
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																									
L	2014	Equinox	Chassis	Electronic Brake Control Module					V																																																				
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2014	Equinox	Chassis	Power Steering Control Module	V	V	V																																																						
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																									V							
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																									V							
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
L	2014	Equinox	Body	Passenger Presence Module																																V																									
L	2014	Equinox	Body	Instrument Cluster																																	V																								
L	2014	Equinox	Body	Radio																																																									
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																			
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																														V											V	V	V	V	V										
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																														V											V	V	V	V	V										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2014	Equinox	Body	Liftgate Control Module																																																									
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Parking Assist Control Module																																V																										
L	2014	Equinox	Body	Frontview Camera Module																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																				V																																					
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																					
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module					V																																																					
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (3GN)	Body	Body Control Module						V	V	V						V				V	V	V																									V												
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																												
L	2015	Captiva (3GN)	Body	Passenger Presence Module																										V																																
L	2015	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2015	Captiva (3GN)	Body	Radio																																																										
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																	V	V	V																							
L	2015	Captiva (3GN)	Body	HVAC Control Module																																											V	V		V	V										
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																					V	V																			
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2015	Captiva (3GN)	Body	Theft Deterrent Module										V																																															
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																					
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																					
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module					V																																																					
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto						V	V	V						V					V	V																																						
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual						V	V	V						V					V	V																									V												
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																												
L	2015	Captiva (Other)	Body	Instrument Cluster																																																										
L	2015	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2015	Captiva (Other)	Body	HVAC Control Module																																																										
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)										V			V																																											
L	2015	Captiva (Other)	Body	Theft Deterrent Module										V																																															
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																				V																												V							
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																								
L	2015	Equinox	Chassis	Electronic Brake Control Module					V																																																			
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2015	Equinox	Chassis	Power Steering Control Module	V	V	V																																																						
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																								V							
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																								V							
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
L	2015	Equinox	Body	Passenger Presence Module																																V																									
L	2015	Equinox	Body	Instrument Cluster																																	V																							
L	2015	Equinox	Body	Radio																																																								
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																		V	V	V																				
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																														V													V	V	V	V	V							
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																														V													V	V	V	V	V							
L	2015	Equinox	Body	Liftgate Control Module																																																								
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																								
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																								
L	2015	Equinox	Body	Parking Assist Control Module																																V																								
L	2015	Equinox	Body	Frontview Camera Module																																																								
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																				V																																				
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																				
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module					V																																																			
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																								
L	2016	Captiva (3GN)	Body	Body Control Module						V	V	V						V				V	V	V																								V												
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
L	2016	Captiva (3GN)	Body	Instrument Cluster																																																								
L	2016	Captiva (3GN)	Body	Radio																																																								
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																								
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																	V	V	V																				
L	2016	Captiva (3GN)	Body	HVAC Control Module																																										V	V		V	V								
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																					V	V																	
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																								
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																								
L	2016	Captiva (3GN)	Body	Theft Deterrent Module										V																																															
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																				V																															V					
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																			V					
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																			V					
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																								
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																				V																																					
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																									
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																				V																																					
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																									
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																									
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module					V																																																				
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																									
L	2016	Captiva (Other)	Chassis	Power Steering Control Module	V	V	V																																																						
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto						V	V	V						V					V	V																																					
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual						V	V	V						V					V	V																									V												
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																									
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
L	2016	Captiva (Other)	Body	Instrument Cluster																																																									
L	2016	Captiva (Other)	Body	Headlamp Control Module																																																									
L	2016	Captiva (Other)	Body	Radio																																																									
L	2016	Captiva (Other)	Body	HVAC Control Module																																																									
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																									
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																									
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																									
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)										V			V																																											
L	2016	Captiva (Other)	Body	Theft Deterrent Module										V																																															
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																				V																													V							
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																					
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																																									
L	2016	Equinox	Chassis	Electronic Brake Control Module					V																																																				
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2016	Equinox	Chassis	Power Steering Control Module	V	V	V																																																						
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																										V						
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																										V						
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
L	2016	Equinox	Body	Passenger Presence Module																																V																										
L	2016	Equinox	Body	Instrument Cluster																																	V																								
L	2016	Equinox	Body	Radio																																																									
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																		V	V	V																				
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																														V											V	V	V	V	V										
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																														V											V	V	V	V	V										
L	2016	Equinox	Body	Liftgate Control Module																																																									
L	2016	Equinox	Body	Seat Memory Control Module																																																									
L	2016	Equinox	Body	Right Side Object Detection Control Module																																																									
L	2016	Equinox	Body	Left Side Object Detection Control Module																																																									
L	2016	Equinox	Body	Parking Assist Control Module																																	V																								
L	2016	Equinox	Body	Frontview Camera Module																																																									
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
M	2004	ALL	Chassis	4WAL 3 Sensor																																																										
M	2004	ALL	Body	Body Control Module																														V																												
M	2004	ALL	Body	Instrument Panel Cluster																																																									
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
M	2005	ALL	Chassis	4WAL 3 Sensor																																																									
M	2005	ALL	Body	Body Control Module																														V																												
M	2005	ALL	Body	Instrument Panel Cluster																																																									
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
P	2007	ALL	Body	Theft Deterrent Module																																																									
R	2009	ALL	Powertrain	Engine Control Module																																																									
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2009	ALL	Powertrain	Transmission Control Module																																																									
R	2009	ALL	Chassis	Electronic Brake Control Module																																																									
R	2009	ALL	Body	Body Control Module																																																									
R	2009	ALL	Body	Digital Radio Receiver																																																									
R	2009	ALL	Body	Driver Door Switch																																																									
R	2009	ALL	Body	Heated Seat Module																																																									
R	2009	ALL	Body	HVAC Control Module Auto																																												V														
R	2009	ALL	Body	HVAC Control Module Manual																																												V														
R	2009	ALL	Body	Instrument Panel Cluster																																																									
R	2009	ALL	Body	Lift Gate Module																																																									
R	2009	ALL	Body	Park Assist Module																																																									
R	2009	ALL	Body	Passenger Door Switch																																																									
R	2009	ALL	Body	Passenger Presence System																																																									
R	2009	ALL	Body	Radio																																																									
R	2009	ALL	Body	Rear HVAC/RSA																																																									
R	2009	ALL	Body	Rollover Sensor																																																									
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2009	ALL	Body	Theft Deterrent Module																																																									
R	2010	ALL	Powertrain	Engine Control Module																																																									
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2010	ALL	Powertrain	Transmission Control Module																																																									
R	2010	ALL	Chassis	Electronic Brake Control Module																																																									
R	2010	ALL	Body	Body Control Module																																																									
R	2010	ALL	Body	Digital Radio Receiver																																																									
R	2010	ALL	Body	Driver Door Switch																																																									
R	2010	ALL	Body	Heated Seat Module																																																									
R	2010	ALL	Body	HVAC Control Module Auto																																												V														
R	2010	ALL	Body	HVAC Control Module Manual																																												V														
R	2010	ALL	Body	Instrument Panel Cluster																																																									
R	2010	ALL	Body	Lift Gate Module																																																									
R	2010	ALL	Body	Park Assist Module																																																									
R	2010	ALL	Body	Passenger Door Switch																																																									
R	2010	ALL	Body	Passenger Presence System																																																									
R	2010	ALL	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2010	ALL	Body	Rear HVAC/RSA																																																								
R	2010	ALL	Body	Supplemental Inflatable Restraint																									V	V																															
R	2010	ALL	Body	Theft Deterrent Module																																																								
R	2011	ALL	Powertrain	Engine Control Module																																																								
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2011	ALL	Powertrain	Transmission Control Module																																																								
R	2011	ALL	Chassis	Electronic Brake Control Module																																																								
R	2011	ALL	Body	Body Control Module																																																								
R	2011	ALL	Body	Digital Radio Receiver																																																								
R	2011	ALL	Body	Driver Door Switch																																																								
R	2011	ALL	Body	Heated Seat Module																																																								
R	2011	ALL	Body	HVAC Control Module Auto																																												V													
R	2011	ALL	Body	HVAC Control Module Manual																																												V													
R	2011	ALL	Body	Instrument Panel Cluster																																																								
R	2011	ALL	Body	Lift Gate Module																																																								
R	2011	ALL	Body	Park Assist Module																																																								
R	2011	ALL	Body	Passenger Door Switch																																																								
R	2011	ALL	Body	Passenger Presence System																																																								
R	2011	ALL	Body	Radio																																																								
R	2011	ALL	Body	Rear HVAC/RSA																																																								
R	2011	ALL	Body	Supplemental Inflatable Restraint																									V	V																															
R	2011	ALL	Body	Theft Deterrent Module																																																								
R	2012	ALL	Powertrain	Engine Control Module																				V																																					
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2012	ALL	Powertrain	Transmission Control Module																																																								
R	2012	ALL	Chassis	Electronic Brake Control Module																																																								
R	2012	ALL	Body	Body Control Module																																																								
R	2012	ALL	Body	Digital Radio Receiver																																																								
R	2012	ALL	Body	Driver Door Switch																																																								
R	2012	ALL	Body	Heated Seat Module																																																								
R	2012	ALL	Body	HVAC Control Module Auto																																												V													
R	2012	ALL	Body	HVAC Control Module Manual																																												V													
R	2012	ALL	Body	Instrument Panel Cluster																																																								
R	2012	ALL	Body	Lift Gate Module																																																								
R	2012	ALL	Body	Park Assist Module																																																								
R	2012	ALL	Body	Passenger Door Switch																																																								
R	2012	ALL	Body	Passenger Presence System																																																								
R	2012	ALL	Body	Radio																																																								
R	2012	ALL	Body	Rear HVAC/RSA																																																								
R	2012	ALL	Body	Supplemental Inflatable Restraint																									V	V																															
R	2012	ALL	Body	Theft Deterrent Module																																																								
R	2013	ALL	Powertrain	Engine Control Module																				V																																					
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2013	ALL	Powertrain	Transmission Control Module																																																								
R	2013	ALL	Chassis	Electronic Brake Control Module																																																								
R	2013	ALL	Body	Body Control Module																																																								
R	2013	ALL	Body	Digital Radio Receiver																																																								
R	2013	ALL	Body	Driver Door Switch																																																								
R	2013	ALL	Body	Heated Seat Module																																																								
R	2013	ALL	Body	HVAC Control Module Auto																																												V													
R	2013	ALL	Body	HVAC Control Module Manual																																												V													

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2013	ALL	Body	Instrument Panel Cluster																																																									
R	2013	ALL	Body	Left Side Object Detection Module																																																										
R	2013	ALL	Body	Lift Gate Module																																																										
R	2013	ALL	Body	Park Assist Module																																																										
R	2013	ALL	Body	Passenger Door Switch																																																										
R	2013	ALL	Body	Passenger Presence System																																																										
R	2013	ALL	Body	Radio																																																										
R	2013	ALL	Body	Rear HVAC/RSA																																																										
R	2013	ALL	Body	Right Side Object Detection Module																																																										
R	2013	ALL	Body	Supplemental Inflatable Restraint																									V	V																																
R	2013	ALL	Body	Theft Deterrent Module																																																										
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																						
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2014	Traverse	Powertrain	Chassis Control Module																																																										
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2014	Traverse	Chassis	Electronic Brake Control Module					V																																																					
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate						V	V	V						V					V	V																																						
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)						V	V	V						V					V	V																																						
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																												
R	2014	Traverse	Body	Passenger Presence Module																										V						V																										
R	2014	Traverse	Body	Instrument Cluster																																																										
R	2014	Traverse	Body	Radio																																																										
R	2014	Traverse	Body	Rear Audio Control Module																																																										
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																										
R	2014	Traverse	Body	Personal Audio Link Control Module																																																										
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																						
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																									V	V		V	V										
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																									V	V		V	V										
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																	V																																								
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
R	2014	Traverse	Body	Liftgate Control Module																																																										
R	2014	Traverse	Body	Seat Memory Control Module																																					V	V																				
R	2014	Traverse	Body	Front Seat Heating Control Module																																					V	V																				
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2014	Traverse	Body	Parking Assist Control Module																																V																										
R	2014	Traverse	Body	Frontview Camera Module																																																										
R	2014	Traverse	Body	Theft Deterrent Module										V																																															
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																						
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2015	Traverse	Chassis	Electronic Brake Control Module					V																																																					
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate						V	V	V						V					V	V																																						
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)						V	V	V						V					V	V																																						
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																												
R	2015	Traverse	Body	Passenger Presence Module																										V						V																										
R	2015	Traverse	Body	Instrument Cluster																																																										
R	2015	Traverse	Body	Radio																																																										
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																			
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																										V	V		V	V								
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																										V	V		V	V								
R	2015	Traverse	Body	Liftgate Control Module																																																							
R	2015	Traverse	Body	Seat Memory Control Module																																					V	V																		
R	2015	Traverse	Body	Front Seat Heating Control Module																																					V	V																		
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																							
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																							
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																							
R	2015	Traverse	Body	Parking Assist Control Module																																V																								
R	2015	Traverse	Body	Frontview Camera Module																																																							
R	2015	Traverse	Body	Theft Deterrent Module										V																																													
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																			
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																							
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																							
R	2016	Traverse	Chassis	Electronic Brake Control Module					V																																																		
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate						V	V	V						V				V	V	V																																			
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)						V	V	V						V				V	V	V																																			
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																									
R	2016	Traverse	Body	Passenger Presence Module																										V						V																							
R	2016	Traverse	Body	Instrument Cluster																																																						
R	2016	Traverse	Body	Radio																																																						
R	2016	Traverse	Body	Rear Audio Control Module																																																						
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																						
R	2016	Traverse	Body	Personal Audio Link Control Module																																																						
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																	V	V	V																				
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																										V	V		V	V								
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																										V	V		V	V								
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																	V																																						
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																						
R	2016	Traverse	Body	Liftgate Control Module																																																						
R	2016	Traverse	Body	Seat Memory Control Module																																					V	V																	
R	2016	Traverse	Body	Front Seat Heating Control Module																																					V	V																	
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																						
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																						
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																						
R	2016	Traverse	Body	Parking Assist Control Module																																V																							
R	2016	Traverse	Body	Frontview Camera Module																																																						
R	2016	Traverse	Body	Theft Deterrent Module										V																																												
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																						
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
S	2004	S10	Chassis	4WAL 3 Sensor																																																						
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																						
S	2004	S10	Body	Body Control Module																														V																							
S	2004	S10	Body	Instrument Panel Cluster																																																						
S	2004	S10	Body	Base Radio																																																						
S	2004	S10	Body	Uplevel Radio																																																						
S	2004	S10	Body	Supplemental Inflatable Restraint																																																						
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																						
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																									
S	2004	Colorado	Chassis	ABS Without Traction Control																																																										
S	2004	Colorado	Chassis	ABS With Traction Control																																																										
S	2004	Colorado	Body	Body Control Module																														V																												
S	2004	Colorado	Body	Instrument Panel Cluster																																																										
S	2004	Colorado	Body	OnStar																																	V																									
S	2004	Colorado	Body	Base Radio																																																										
S	2004	Colorado	Body	Uplevel Radio																																																										
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																										
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																										
S	2004	TrailBlazer	Body	Body Control Module																																																										
S	2004	TrailBlazer	Body	Driver Door Module																																																										
S	2004	TrailBlazer	Body	Driver Seat Module																																																										
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																																										
S	2004	TrailBlazer	Body	Lift Gate Module																																																										
S	2004	TrailBlazer	Body	OnStar																																	V																									
S	2004	TrailBlazer	Body	Passenger Door Module																																																										
S	2004	TrailBlazer	Body	Uplevel Radio																																																										
S	2004	TrailBlazer	Body	Navigation Radio																																																										
S	2004	TrailBlazer	Body	Rear Seat Audio																																																										
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																										
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																										
S	2004	TrailBlazer EXT	Body	Body Control Module																																																										
S	2004	TrailBlazer EXT	Body	Driver Door Module																																																										
S	2004	TrailBlazer EXT	Body	Driver Seat Module																																																										
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																										
S	2004	TrailBlazer EXT	Body	OnStar																																	V																									
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																																										
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																										
S	2004	TrailBlazer EXT	Body	Navigation Radio																																																										
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																										
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																										
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Blazer	Body	Body Control Module																														V																												
S	2004	Blazer	Body	Heating and Air Conditioning																																																										
S	2004	Blazer	Body	Instrument Panel Cluster																																																										
S	2004	Blazer	Body	Memory Seat Module																																																										
S	2004	Blazer	Body	Base Radio																																																										
S	2004	Blazer	Body	Uplevel Radio																																																										
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																																										
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	SSR	Chassis	4WAL 3 Sensor																																																										
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																										
S	2004	SSR	Body	Amplifier (Bose)																																																										
S	2004	SSR	Body	Body Control Module																														V																												
S	2004	SSR	Body	Driver Seat Module																																																										
S	2004	SSR	Body	Instrument Panel Cluster																																																										
S	2004	SSR	Body	Uplevel Radio																																																										
S	2004	SSR	Body	Remote Function Actuation																																																										
S	2004	SSR	Body	Roof and Door Module																																																										
S	2004	SSR	Body	Supplemental Inflatable Restraint																																																										
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2005	Colorado	Chassis	ABS Without Traction Control																																																										
S	2005	Colorado	Chassis	ABS With Traction Control																																																										
S	2005	Colorado	Body	Body Control Module																														V																												
S	2005	Colorado	Body	Instrument Panel Cluster																																																										
S	2005	Colorado	Body	Base Radio																																																										
S	2005	Colorado	Body	Uplevel Radio																																																										
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																	V																									
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																										
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
S	2005	TrailBlazer	Body	Body Control Module																																																										
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2005	TrailBlazer	Body	Driver Door Module																																																										
S	2005	TrailBlazer	Body	Driver Seat Module																																																										
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2005	TrailBlazer	Body	Lift Gate Module																																																									
S	2005	TrailBlazer	Body	Passenger Door Module																																																										
S	2005	TrailBlazer	Body	Passenger Presence System																																																										
S	2005	TrailBlazer	Body	Uplevel Radio																																																										
S	2005	TrailBlazer	Body	Navigation Radio																																																										
S	2005	TrailBlazer	Body	Rear Seat Audio																																																										
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																V																										
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
S	2005	TrailBlazer EXT	Body	Body Control Module																																																										
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
S	2005	TrailBlazer EXT	Body	Driver Door Module																																																										
S	2005	TrailBlazer EXT	Body	Driver Seat Module																																																										
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																										
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																																										
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																										
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																										
S	2005	TrailBlazer EXT	Body	Navigation Radio																																																										
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																										
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																V																										
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																										
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Blazer	Body	Body Control Module																														V																										
S	2005	Blazer	Body	Heating and Air Conditioning																																																										
S	2005	Blazer	Body	Instrument Panel Cluster																																																										
S	2005	Blazer	Body	Memory Seat Module																																																										
S	2005	Blazer	Body	Base Radio																																																										
S	2005	Blazer	Body	Uplevel Radio																																																										
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																																										
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2005	SSR	Chassis	4WAL 3 Sensor																																																										
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																										
S	2005	SSR	Body	Amplifier (Bose)																																																										
S	2005	SSR	Body	Body Control Module																														V																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2005	SSR	Body	Driver Seat Module																																																									
S	2005	SSR	Body	Instrument Panel Cluster																																																									
S	2005	SSR	Body	Uplevel Radio																																																									
S	2005	SSR	Body	Remote Function Actuation																																																									
S	2005	SSR	Body	Roof and Door Module																																																									
S	2005	SSR	Body	Supplemental Inflatable Restraint																																																									
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																									
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																									
S	2006	Colorado	Chassis	ABS Without Traction Control																																																									
S	2006	Colorado	Chassis	ABS With Traction Control																																																									
S	2006	Colorado	Body	Body Control Module																														V																												
S	2006	Colorado	Body	Instrument Panel Cluster																																																									
S	2006	Colorado	Body	Passenger Presence System																																																									
S	2006	Colorado	Body	Base Radio																																																									
S	2006	Colorado	Body	Uplevel Radio																																																									
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																																									
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																	V																									
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																									
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																									
S	2006	TrailBlazer	Body	Body Control Module																														V																												
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																									
S	2006	TrailBlazer	Body	Driver Door Module																																																									
S	2006	TrailBlazer	Body	Driver Seat Module																																																									
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																									
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																									
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																																									
S	2006	TrailBlazer	Body	Lift Gate Module																																																									
S	2006	TrailBlazer	Body	Passenger Door Module																																																									
S	2006	TrailBlazer	Body	Passenger Presence System																																																									
S	2006	TrailBlazer	Body	Uplevel Radio																																																									
S	2006	TrailBlazer	Body	Navigation Radio																																																									
S	2006	TrailBlazer	Body	Rear Seat Audio																																																									
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																									
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																									
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																	V																								
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																									
S	2006	TrailBlazer EXT	Body	Body Control Module																														V																												
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																									
S	2006	TrailBlazer EXT	Body	Driver Door Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2006	TrailBlazer EXT	Body	Driver Seat Module																																																									
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																									
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																									
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																									
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																									
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																																									
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																									
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																									
S	2006	TrailBlazer EXT	Body	Navigation Radio																																																									
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																									
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																									
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																									
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																									
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																									
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																V																									
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
S	2006	SSR	Chassis	4WAL 3 Sensor																																																									
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																									
S	2006	SSR	Body	Amplifier (Bose)																																																									
S	2006	SSR	Body	Body Control Module																														V																											
S	2006	SSR	Body	Driver Seat Module																																																									
S	2006	SSR	Body	Instrument Panel Cluster																																																									
S	2006	SSR	Body	Uplevel Radio																																																									
S	2006	SSR	Body	Remote Function Actuation																																																									
S	2006	SSR	Body	Roof and Door Module																																																									
S	2006	SSR	Body	Supplemental Inflatable Restraint																																																									
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																									
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																									
S	2007	Colorado	Body	Body Control Module																														V																											
S	2007	Colorado	Body	Digital Radio Receiver																																																									
S	2007	Colorado	Body	Generator Battery Control Module																																																									
S	2007	Colorado	Body	Instrument Panel Cluster																																																									
S	2007	Colorado	Body	Passenger Presence System																																																									
S	2007	Colorado	Body	Base Radio																																																									
S	2007	Colorado	Body	Uplevel Radio																																																									
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																																									
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																V																									
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																									
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																									
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2007	Trailblazer	Body	Body Control Module																															V																											
S	2007	Trailblazer	Body	Digital Radio Receiver																																																									
S	2007	Trailblazer	Body	Disc Player and Video Display																																																									
S	2007	Trailblazer	Body	Driver Door Module																																																									
S	2007	Trailblazer	Body	Driver Seat Module																																																									
S	2007	Trailblazer	Body	Generator Battery Control Module																																																									
S	2007	Trailblazer	Body	HVAC Control Module Auto																																																									
S	2007	Trailblazer	Body	HVAC Control Module Manual																																																									
S	2007	Trailblazer	Body	Instrument Panel Cluster																																																									
S	2007	Trailblazer	Body	Lift Gate Module																																																									
S	2007	Trailblazer	Body	Passenger Door Module																																																									
S	2007	Trailblazer	Body	Passenger Presence System																																																									
S	2007	Trailblazer	Body	Uplevel Radio																																																									
S	2007	Trailblazer	Body	Navigation Radio																																																									
S	2007	Trailblazer	Body	Rear Seat Audio																																																									
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																									
S	2007	Trailblazer	Body	Theft Deterrent Module																																																									
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																	V																									
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																									
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																									
S	2008	Colorado	Body	Body Control Module																															V																											
S	2008	Colorado	Body	Digital Radio Receiver																																																									
S	2008	Colorado	Body	Generator Battery Control Module																																																									
S	2008	Colorado	Body	Instrument Panel Cluster																																																									
S	2008	Colorado	Body	Passenger Presence System																																																									
S	2008	Colorado	Body	Base Radio																																																									
S	2008	Colorado	Body	Uplevel Radio																																																									
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																																									
S	2008	Colorado	Body	Theft Deterrent Module																																																									
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																	V																									
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																									
S	2008	TrailBlazer	Body	Body Control Module																															V																											
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																									
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																									
S	2008	TrailBlazer	Body	Driver Door Module																																																									
S	2008	TrailBlazer	Body	Driver Seat Module																																																									
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																									
S	2008	TrailBlazer	Body	HVAC Control Module Auto																																																									
S	2008	TrailBlazer	Body	HVAC Control Module Manual																																																									
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																																									
S	2008	TrailBlazer	Body	Lift Gate Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2008	TrailBlazer	Body	Passenger Door Module																																																									
S	2008	TrailBlazer	Body	Passenger Presence System																																																										
S	2008	TrailBlazer	Body	Uplevel Radio																																																										
S	2008	TrailBlazer	Body	Navigation Radio																																																										
S	2008	TrailBlazer	Body	Rear Seat Audio																																																										
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2008	TrailBlazer	Body	Theft Deterrent Module																																																										
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																V																										
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																										
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
S	2009	Colorado	Chassis	Electronic Brake Control Module																																																										
S	2009	Colorado	Body	Body Control Module																														V																												
S	2009	Colorado	Body	Digital Radio Receiver																																																										
S	2009	Colorado	Body	Generator Battery Control Module																																																										
S	2009	Colorado	Body	Instrument Panel Cluster																																																										
S	2009	Colorado	Body	Passenger Presence System																																																										
S	2009	Colorado	Body	Base Radio																																																										
S	2009	Colorado	Body	Uplevel Radio																																																										
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2009	Colorado	Body	Theft Deterrent Module																																																										
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																										
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																										
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																										
S	2009	TrailBlazer	Body	Body Control Module																														V																												
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																										
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2009	TrailBlazer	Body	Driver Door Module																																																										
S	2009	TrailBlazer	Body	Driver Seat Module																																																										
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																										
S	2009	TrailBlazer	Body	HVAC Control Module Auto																																																										
S	2009	TrailBlazer	Body	HVAC Control Module Manual																																																										
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																																										
S	2009	TrailBlazer	Body	Lift Gate Module																																																										
S	2009	TrailBlazer	Body	Passenger Door Module																																																										
S	2009	TrailBlazer	Body	Passenger Presence System																																																										
S	2009	TrailBlazer	Body	Uplevel Radio																																																										
S	2009	TrailBlazer	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2009	TrailBlazer	Body	Rear Seat Audio																																																								
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																								
S	2009	TrailBlazer	Body	Theft Deterrent Module																																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
S	2010	ALL	Chassis	Electronic Brake Control Module																																																								
S	2010	ALL	Body	Body Control Module																															V																									
S	2010	ALL	Body	Digital Radio Receiver																																																								
S	2010	ALL	Body	Generator Battery Control Module																																																								
S	2010	ALL	Body	Instrument Panel Cluster																																																								
S	2010	ALL	Body	Passenger Presence System																																																								
S	2010	ALL	Body	Personal Audio Link Module																																																								
S	2010	ALL	Body	Base Radio																																																								
S	2010	ALL	Body	Uplevel Radio																																																								
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
S	2010	ALL	Body	Theft Deterrent Module																																																								
S	2010	ALL	Body	Vehicle Comm. Interface Module																																	V		V																					
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
S	2011	ALL	Chassis	Electronic Brake Control Module																																																								
S	2011	ALL	Body	Body Control Module																															V																									
S	2011	ALL	Body	Digital Radio Receiver																																																								
S	2011	ALL	Body	Generator Battery Control Module																																																								
S	2011	ALL	Body	Instrument Panel Cluster																																																								
S	2011	ALL	Body	Passenger Presence System																																																								
S	2011	ALL	Body	Personal Audio Link Module																																																								
S	2011	ALL	Body	Base Radio																																																								
S	2011	ALL	Body	Uplevel Radio																																																								
S	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
S	2011	ALL	Body	Theft Deterrent Module																																																								
S	2011	ALL	Body	Vehicle Comm. Interface Module																																	V		V																					
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																								
S	2012	Colorado (First Gen)	Body	Body Control Module																														V																											
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																								
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																								
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																								
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																								
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																								
S	2012	Colorado (First Gen)	Body	Base Radio																																																								
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																								
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																								
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																								
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																V		V																					
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																								
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																				V																																				
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																								
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																								
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																								
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
S	2012	Colorado (Second Gen)	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																						V														
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																								
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																V																								
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																								
S	2012	S10	Powertrain	Transfer Case Control Module																																																								
S	2012	S10	Chassis	Electronic Brake Control Module																																																								
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
S	2012	S10	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																						V														
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
S	2012	S10	Body	Instrument Cluster																																																								
S	2012	S10	Body	Trailer Interface Control Module																																V																								
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																								
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																				V																																				
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																								
S	2013	Colorado	Powertrain	Transfer Case Control Module																																																								
S	2013	Colorado	Chassis	Electronic Brake Control Module																																																								
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
S	2013	Colorado	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																								V												
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
S	2013	Colorado	Body	Instrument Cluster																																	V																							
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																								
S	2013	S10	Powertrain	Transfer Case Control Module																																																								
S	2013	S10	Chassis	Electronic Brake Control Module																																																								
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
S	2013	S10	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																								V												
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
S	2013	S10	Body	Instrument Cluster																																																								
S	2013	S10	Body	Trailer Interface Control Module																																	V																							
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																								
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																				
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																				V																																				
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																								
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																								
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																								
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
S	2013	Trailblazer	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																								V												
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
S	2013	Trailblazer	Body	Instrument Cluster																																	V																							
S	2013	Trailblazer	Body	Trailer Interface Control Module																																	V																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2013	Trailblazer	Body	Parking Assist Control Module																																	V																							
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																							
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																						
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																			V				
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																			V				
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																															V				
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																			V				
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																							
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																				V																																				
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																							
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																							
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																							
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																						
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																						
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
S	2014	Colorado	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																							V											
S	2014	Colorado	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																							V											
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
S	2014	Colorado	Body	Instrument Cluster																																	V																						
S	2014	Colorado	Body	Radio																																																						
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																		V	V	V	V																	
S	2014	Colorado	Body	Parking Assist Control Module																																	V																					
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																						
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																						
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																						
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																						
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																			V				
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																			V				
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																															V				
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																			V				
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																							
S	2014	S10	Powertrain	Transfer Case Control Module																																																						
S	2014	S10	Chassis	Electronic Brake Control Module																																																						
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																						
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
S	2014	S10	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																							V											
S	2014	S10	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																							V											
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
S	2014	S10	Body	Instrument Cluster																																	V																						
S	2014	S10	Body	Trailer Interface Control Module																																	V																						
S	2014	S10	Body	Radio																																																						
S	2014	S10	Body	Parking Assist Control Module																																	V																						
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																			V				
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																			V				
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																															V				
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																			V				
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																						
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																				V																																			
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																						
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																						
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																								
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
S	2014	Trailblazer	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																								V												
S	2014	Trailblazer	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																								V												
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
S	2014	Trailblazer	Body	Instrument Cluster																																V																								
S	2014	Trailblazer	Body	Trailer Interface Control Module																																V																								
S	2014	Trailblazer	Body	Parking Assist Control Module																																V																								
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																				
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																		V						
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																		V						
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																														V						
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																		V						
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																				
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2015	Colorado	Powertrain	Chassis Control Module																																																				V	V			
S	2015	Colorado	Powertrain	Transfer Case Control Module																																																								
S	2015	Colorado	Chassis	Electronic Brake Control Module					V																																																			
S	2015	Colorado	Chassis	Power Steering Control Module				V	V																																																			
S	2015	Colorado	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																											V						
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
S	2015	Colorado	Body	Passenger Presence Module																															V																									
S	2015	Colorado	Body	Radio																																																								
S	2015	Colorado	Body	Amplifier																																																								
S	2015	Colorado	Body	Human Machine Interface Control Module																																																								
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																	V	V	V																					
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																														V													V	V	V	V										
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																														V													V	V	V	V										
S	2015	Colorado	Body	Frontview Camera Module																																																								
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																				
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																		V						
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																		V						
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																														V						
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																		V						
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																				
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																								
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																								
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
S	2015	Colorado (MMM)	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																								V												
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2015	Colorado (MMM)	Body	Instrument Cluster																																V																								
S	2015	Colorado (MMM)	Body	Radio																																																								
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																	V	V	V																				
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																V																								
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																				
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																				V				
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																				V				
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																																V				
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																				V				
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2015	S10	Powertrain	Transfer Case Control Module																																																								
S	2015	S10	Chassis	Electronic Brake Control Module																																																								
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
S	2015	S10	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																								V												
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
S	2015	S10	Body	Instrument Cluster																																V																								
S	2015	S10	Body	Trailer Interface Control Module																																V																								
S	2015	S10	Body	Radio																																																								
S	2015	S10	Body	Telematics Communication Interface Control Module																																	V	V	V																				
S	2015	S10	Body	Parking Assist Control Module																																V																								
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																			V				
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																			V				
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																																V				
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																			V				
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																				
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																								
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																								
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
S	2015	Trailblazer	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																								V												
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
S	2015	Trailblazer	Body	Instrument Cluster																																V																								
S	2015	Trailblazer	Body	Trailer Interface Control Module																																V																								
S	2015	Trailblazer	Body	Radio																																																							
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																	V	V	V																				
S	2015	Trailblazer	Body	Parking Assist Control Module																																V																								
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																				
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																								
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																											
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module					V																																																					
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module				V	V																																																					
S	2016	Colorado (1GC)	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																							V									
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																V																										
S	2016	Colorado (1GC)	Body	Radio Controls																																																									
S	2016	Colorado (1GC)	Body	HVAC Controls																																																									
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																	V																								
S	2016	Colorado (1GC)	Body	Radio																																																									
S	2016	Colorado (1GC)	Body	Amplifier																																																									
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																									
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																						
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																						
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V										
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V										
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																																									
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																					
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																				V																																				
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																								
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																								
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
S	2016	Colorado (MMM)	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																						V														
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
S	2016	Colorado (MMM)	Body	Instrument Cluster																																	V																								
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																	V																								
S	2016	Colorado (MMM)	Body	Radio																																																									
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																		V	V	V																					
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V										
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V										
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																	V																								
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																									
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																					
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																				V																																				
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
S	2016	S10	Powertrain	Transfer Case Control Module																																																									
S	2016	S10	Chassis	Electronic Brake Control Module																																																								
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
S	2016	S10	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																						V														

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
S	2016	S10	Body	Instrument Cluster																																	V																						
S	2016	S10	Body	Trailer Interface Control Module																																	V																						
S	2016	S10	Body	Radio																																																							
S	2016	S10	Body	Telematics Communication Interface Control Module																																		V	V	V																				
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V									
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V									
S	2016	S10	Body	Parking Assist Control Module																																	V																						
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																			V			
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																			V			
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																				V																															V			
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																			V			
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																						
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																			
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																						
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																						
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																						
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
S	2016	Trailblazer	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																						V												
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
S	2016	Trailblazer	Body	Instrument Cluster																																	V																						
S	2016	Trailblazer	Body	Trailer Interface Control Module																																	V																						
S	2016	Trailblazer	Body	Radio																																																						
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																		V	V	V																				
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V									
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V									
S	2016	Trailblazer	Body	Parking Assist Control Module																																	V																						
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																						
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																						
T	2004	S10	Chassis	4WAL 3 Sensor																																																						
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																						
T	2004	S10	Body	Body Control Module																														V																								
T	2004	S10	Body	Instrument Panel Cluster																																																						
T	2004	S10	Body	Base Radio																																																						
T	2004	S10	Body	Uplevel Radio																																																						
T	2004	S10	Body	Supplemental Inflatable Restraint																																																						
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																						
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																						
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																						
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																						
T	2004	Colorado	Chassis	ABS Without Traction Control																																																						
T	2004	Colorado	Chassis	ABS With Traction Control																																																						
T	2004	Colorado	Body	Body Control Module																														V																								
T	2004	Colorado	Body	Instrument Panel Cluster																																																						
T	2004	Colorado	Body	OnStar																																		V																						
T	2004	Colorado	Body	Base Radio																																																						
T	2004	Colorado	Body	Uplevel Radio																																																						
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																																						
T	2004	Colorado	Body	Instrument Panel Cluster																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer	Body	Body Control Module																																																										
T	2004	TrailBlazer	Body	Driver Door Module																																																										
T	2004	TrailBlazer	Body	Driver Seat Module																																																										
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2004	TrailBlazer	Body	Lift Gate Module																																																										
T	2004	TrailBlazer	Body	OnStar																																V																										
T	2004	TrailBlazer	Body	Passenger Door Module																																																										
T	2004	TrailBlazer	Body	Uplevel Radio																																																										
T	2004	TrailBlazer	Body	Navigation Radio																																																										
T	2004	TrailBlazer	Body	Rear Seat Audio																																																										
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer EXT	Body	Body Control Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Seat Module																																																										
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2004	TrailBlazer EXT	Body	OnStar																																V																										
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2004	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																										
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Blazer	Body	Body Control Module																														V																												
T	2004	Blazer	Body	Heating and Air Conditioning																																																										
T	2004	Blazer	Body	Instrument Panel Cluster																																																										
T	2004	Blazer	Body	Memory Seat Module																																																										
T	2004	Blazer	Body	Base Radio																																																										
T	2004	Blazer	Body	Uplevel Radio																																																										
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																																										
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2005	Colorado	Chassis	ABS Without Traction Control																																																										
T	2005	Colorado	Chassis	ABS With Traction Control																																																										
T	2005	Colorado	Body	Body Control Module																														V																												
T	2005	Colorado	Body	Instrument Panel Cluster																																																										
T	2005	Colorado	Body	Base Radio																																																										
T	2005	Colorado	Body	Uplevel Radio																																																										
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																	V																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																										
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
T	2005	TrailBlazer	Body	Body Control Module																																																										
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2005	TrailBlazer	Body	Driver Door Module																																																										
T	2005	TrailBlazer	Body	Driver Seat Module																																																										
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2005	TrailBlazer	Body	Lift Gate Module																																																										
T	2005	TrailBlazer	Body	Passenger Door Module																																																										
T	2005	TrailBlazer	Body	Passenger Presence System																																																										
T	2005	TrailBlazer	Body	Uplevel Radio																																																										
T	2005	TrailBlazer	Body	Navigation Radio																																																										
T	2005	TrailBlazer	Body	Rear Seat Audio																																																										
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																	V																									
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																									
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
T	2005	TrailBlazer EXT	Body	Body Control Module																																																										
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
T	2005	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2005	TrailBlazer EXT	Body	Driver Seat Module																																																										
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																										
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2005	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																										
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																	V																									
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																										
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Blazer	Body	Body Control Module																														V																												
T	2005	Blazer	Body	Heating and Air Conditioning																																																										
T	2005	Blazer	Body	Instrument Panel Cluster																																																										
T	2005	Blazer	Body	Memory Seat Module																																																										
T	2005	Blazer	Body	Base Radio																																																										
T	2005	Blazer	Body	Uplevel Radio																																																										
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																																										
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2006	Colorado	Chassis	ABS Without Traction Control																																																										
T	2006	Colorado	Chassis	ABS With Traction Control																																																										
T	2006	Colorado	Body	Body Control Module																														V																												
T	2006	Colorado	Body	Instrument Panel Cluster																																																										
T	2006	Colorado	Body	Passenger Presence System																																																										
T	2006	Colorado	Body	Base Radio																																																										
T	2006	Colorado	Body	Uplevel Radio																																																										
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																	V																									
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																								
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																								
T	2006	TrailBlazer	Body	Body Control Module																															V																									
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																								
T	2006	TrailBlazer	Body	Driver Door Module																																																								
T	2006	TrailBlazer	Body	Driver Seat Module																																																								
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																								
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																								
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																																								
T	2006	TrailBlazer	Body	Lift Gate Module																																																								
T	2006	TrailBlazer	Body	Passenger Door Module																																																								
T	2006	TrailBlazer	Body	Passenger Presence System																																																								
T	2006	TrailBlazer	Body	Uplevel Radio																																																								
T	2006	TrailBlazer	Body	Navigation Radio																																																								
T	2006	TrailBlazer	Body	Rear Seat Audio																																																								
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																								
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																								
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																	V																							
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																								
T	2006	TrailBlazer EXT	Body	Body Control Module																															V																									
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																								
T	2006	TrailBlazer EXT	Body	Driver Door Module																																																								
T	2006	TrailBlazer EXT	Body	Driver Seat Module																																																								
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																								
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																								
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																								
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																								
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																																								
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																								
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																								
T	2006	TrailBlazer EXT	Body	Navigation Radio																																																								
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																								
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																								
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																								
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																								
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																								
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																	V																							
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																									
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																									
T	2007	Colorado	Body	Body Control Module																														V																												
T	2007	Colorado	Body	Digital Radio Receiver																																																									
T	2007	Colorado	Body	Generator Battery Control Module																																																									
T	2007	Colorado	Body	Instrument Panel Cluster																																																									
T	2007	Colorado	Body	Passenger Presence System																																																									
T	2007	Colorado	Body	Base Radio																																																									
T	2007	Colorado	Body	Uplevel Radio																																																									
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																																									
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																	V																									
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																									
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																									
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																									
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																									
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																									
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																									
T	2007	Trailblazer	Body	Body Control Module																														V																												
T	2007	Trailblazer	Body	Digital Radio Receiver																																																									
T	2007	Trailblazer	Body	Disc Player and Video Display																																																									
T	2007	Trailblazer	Body	Driver Door Module																																																									
T	2007	Trailblazer	Body	Driver Seat Module																																																									
T	2007	Trailblazer	Body	Generator Battery Control Module																																																									
T	2007	Trailblazer	Body	HVAC Control Module Auto																																																									
T	2007	Trailblazer	Body	HVAC Control Module Manual																																																									
T	2007	Trailblazer	Body	Instrument Panel Cluster																																																									
T	2007	Trailblazer	Body	Lift Gate Module																																																									
T	2007	Trailblazer	Body	Passenger Door Module																																																									
T	2007	Trailblazer	Body	Passenger Presence System																																																									
T	2007	Trailblazer	Body	Uplevel Radio																																																									
T	2007	Trailblazer	Body	Navigation Radio																																																									
T	2007	Trailblazer	Body	Rear Seat Audio																																																									
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																									
T	2007	Trailblazer	Body	Theft Deterrent Module																																																									
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																	V																									
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																									
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																									
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																									
T	2008	Colorado	Body	Body Control Module																														V																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2008	Colorado	Body	Digital Radio Receiver																																																								
T	2008	Colorado	Body	Generator Battery Control Module																																																								
T	2008	Colorado	Body	Instrument Panel Cluster																																																								
T	2008	Colorado	Body	Passenger Presence System																																																								
T	2008	Colorado	Body	Base Radio																																																								
T	2008	Colorado	Body	Uplevel Radio																																																								
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																																								
T	2008	Colorado	Body	Theft Deterrent Module																																																								
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																	V																							
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																								
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																								
T	2008	TrailBlazer	Body	Body Control Module																														V																										
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																								
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																								
T	2008	TrailBlazer	Body	Driver Door Module																																																								
T	2008	TrailBlazer	Body	Driver Seat Module																																																								
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																								
T	2008	TrailBlazer	Body	HVAC Control Module Auto																																																								
T	2008	TrailBlazer	Body	HVAC Control Module Manual																																																								
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																																								
T	2008	TrailBlazer	Body	Lift Gate Module																																																								
T	2008	TrailBlazer	Body	Passenger Door Module																																																								
T	2008	TrailBlazer	Body	Passenger Presence System																																																								
T	2008	TrailBlazer	Body	Uplevel Radio																																																								
T	2008	TrailBlazer	Body	Navigation Radio																																																								
T	2008	TrailBlazer	Body	Rear Seat Audio																																																								
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																								
T	2008	TrailBlazer	Body	Theft Deterrent Module																																																								
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																	V																							
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																								
T	2009	Colorado	Chassis	Electronic Brake Control Module																																																								
T	2009	Colorado	Body	Body Control Module																														V																										
T	2009	Colorado	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2009	Colorado	Body	Generator Battery Control Module																																																									
T	2009	Colorado	Body	Instrument Panel Cluster																																																										
T	2009	Colorado	Body	Passenger Presence System																																																										
T	2009	Colorado	Body	Base Radio																																																										
T	2009	Colorado	Body	Uplevel Radio																																																										
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2009	Colorado	Body	Theft Deterrent Module																																																										
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																										
T	2009	TrailBlazer	Body	Body Control Module																														V																													
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																										
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2009	TrailBlazer	Body	Driver Door Module																																																										
T	2009	TrailBlazer	Body	Driver Seat Module																																																										
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																										
T	2009	TrailBlazer	Body	HVAC Control Module Auto																																																										
T	2009	TrailBlazer	Body	HVAC Control Module Manual																																																										
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2009	TrailBlazer	Body	Lift Gate Module																																																										
T	2009	TrailBlazer	Body	Passenger Door Module																																																										
T	2009	TrailBlazer	Body	Passenger Presence System																																																										
T	2009	TrailBlazer	Body	Uplevel Radio																																																										
T	2009	TrailBlazer	Body	Navigation Radio																																																										
T	2009	TrailBlazer	Body	Rear Seat Audio																																																										
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2009	TrailBlazer	Body	Theft Deterrent Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
T	2010	ALL	Chassis	Electronic Brake Control Module																																																										
T	2010	ALL	Body	Body Control Module																														V																												
T	2010	ALL	Body	Digital Radio Receiver																																																										
T	2010	ALL	Body	Generator Battery Control Module																																																										
T	2010	ALL	Body	Instrument Panel Cluster																																																										
T	2010	ALL	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2010	ALL	Body	Personal Audio Link Module																																																								
T	2010	ALL	Body	Base Radio																																																								
T	2010	ALL	Body	Uplevel Radio																																																								
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2010	ALL	Body	Theft Deterrent Module																																																								
T	2010	ALL	Body	Vehicle Comm. Interface Module																																V		V																						
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																								
T	2011	ALL	Chassis	Electronic Brake Control Module																																																								
T	2011	ALL	Body	Body Control Module																														V																										
T	2011	ALL	Body	Digital Radio Receiver																																																								
T	2011	ALL	Body	Generator Battery Control Module																																																								
T	2011	ALL	Body	Instrument Panel Cluster																																																								
T	2011	ALL	Body	Passenger Presence System																																																								
T	2011	ALL	Body	Personal Audio Link Module																																																								
T	2011	ALL	Body	Base Radio																																																								
T	2011	ALL	Body	Uplevel Radio																																																								
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2011	ALL	Body	Theft Deterrent Module																																																								
T	2011	ALL	Body	Vehicle Comm. Interface Module																																V		V																						
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																								
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																								
T	2012	Colorado (First Gen)	Body	Body Control Module																														V																										
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																								
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																								
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																								
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																								
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																								
T	2012	Colorado (First Gen)	Body	Base Radio																																																								
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																								
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																									
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																V		V																						
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																							
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																							
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																							
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																							
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																							
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																				V																																				
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																							
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																							
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																							
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																							
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
T	2012	Colorado (Second Gen)	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																							V													
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																							
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																V																								
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																							
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																							
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																							
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																							
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																							
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																							
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																							
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																							
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																							
T	2012	S10	Powertrain	Transfer Case Control Module																																																							
T	2012	S10	Chassis	Electronic Brake Control Module																																																							
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																							
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
T	2012	S10	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																							V													
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
T	2012	S10	Body	Instrument Cluster																																																						
T	2012	S10	Body	Trailer Interface Control Module																																V																								
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																							
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																							
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																							
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																							
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																							
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																							
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																							
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																				V																																				
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																							
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																							
T	2013	Colorado	Powertrain	Transfer Case Control Module																																																							
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																							
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																							
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2013	Colorado	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																							V											
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
T	2013	Colorado	Body	Instrument Cluster																																V																						
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																					
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																					
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																					
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																					
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																					
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																					
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																					
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																					
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																					
T	2013	S10	Powertrain	Transfer Case Control Module																																																					
T	2013	S10	Chassis	Electronic Brake Control Module																																																					
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																					
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module				V	V																																																
T	2013	S10	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																							V											
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
T	2013	S10	Body	Instrument Cluster																																																					
T	2013	S10	Body	Trailer Interface Control Module																																V																						
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																					
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																					
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																					
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																					
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																					
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																		
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																					
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																					
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																				V																																		
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																					
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																					
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																					
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																					
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																					
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module				V	V																																																
T	2013	Trailblazer	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																							V											
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
T	2013	Trailblazer	Body	Instrument Cluster																																V																						
T	2013	Trailblazer	Body	Trailer Interface Control Module																																V																						
T	2013	Trailblazer	Body	Parking Assist Control Module																																V																						
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																					
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																					
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																		V			
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																	V			
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																													V			
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																	V			
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																				
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																				V																																	
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																				
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																				
T	2014	Colorado	Powertrain	Transfer Case Control Module																																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																								
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
T	2014	Colorado	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																									V											
T	2014	Colorado	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																									V											
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
T	2014	Colorado	Body	Instrument Cluster																																	V																							
T	2014	Colorado	Body	Radio																																																								
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																		V	V	V	V																			
T	2014	Colorado	Body	Parking Assist Control Module																																	V																							
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																		V						
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																		V						
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																														V						
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																		V						
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																								
T	2014	S10	Powertrain	Transfer Case Control Module																																																								
T	2014	S10	Chassis	Electronic Brake Control Module																																																								
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
T	2014	S10	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																									V											
T	2014	S10	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																									V											
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
T	2014	S10	Body	Instrument Cluster																																	V																							
T	2014	S10	Body	Trailer Interface Control Module																																	V																							
T	2014	S10	Body	Radio																																																								
T	2014	S10	Body	Parking Assist Control Module																																	V																							
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																		V						
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																		V						
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																														V						
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																		V						
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																								
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																				V																																				
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																								
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																								
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
T	2014	Trailblazer	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																									V											
T	2014	Trailblazer	Body	Body Control Module						V	V	V	V	V		V		V	V		V		V	V																									V											
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
T	2014	Trailblazer	Body	Instrument Cluster																																	V																							
T	2014	Trailblazer	Body	Trailer Interface Control Module																																	V																							
T	2014	Trailblazer	Body	Parking Assist Control Module																																	V																							
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																				
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																																				
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																							
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																							
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																			
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																							
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																							
T	2015	Colorado	Powertrain	Chassis Control Module																																																			V	V		
T	2015	Colorado	Powertrain	Transfer Case Control Module																																																						
T	2015	Colorado	Chassis	Electronic Brake Control Module					V																																																	
T	2015	Colorado	Chassis	Power Steering Control Module				V	V																																																	
T	2015	Colorado	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																							V						
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																						
T	2015	Colorado	Body	Passenger Presence Module																																V																					
T	2015	Colorado	Body	Radio																																																						
T	2015	Colorado	Body	Amplifier																																																					
T	2015	Colorado	Body	Human Machine Interface Control Module																																																					
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																	V	V	V																		
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																														V											V	V	V	V							
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																														V											V	V	V	V							
T	2015	Colorado	Body	Frontview Camera Module																																																				
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																			
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																						
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																						
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																					
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																					
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																																		
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																					
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																					
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																		
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																					
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																					
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																					
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																					
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																					
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module				V	V																																																
T	2015	Colorado (MMM)	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																					V												
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																						
T	2015	Colorado (MMM)	Body	Instrument Cluster																																V																					
T	2015	Colorado (MMM)	Body	Radio																																																					
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																	V	V	V																		
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																V																					
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																					
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																					
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																		
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																					
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																					
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																				
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																				
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																																	

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																						V				
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	S10	Powertrain	Transfer Case Control Module																																																									
T	2015	S10	Chassis	Electronic Brake Control Module																																																									
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
T	2015	S10	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																								V												
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
T	2015	S10	Body	Instrument Cluster																																V																									
T	2015	S10	Body	Trailer Interface Control Module																																V																									
T	2015	S10	Body	Radio																																																									
T	2015	S10	Body	Telematics Communication Interface Control Module																																	V	V	V																						
T	2015	S10	Body	Parking Assist Control Module																																V																									
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																						V				
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																					V				
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																				V																																V				
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																				V				
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																				
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																									
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																									
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
T	2015	Trailblazer	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																								V												
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
T	2015	Trailblazer	Body	Instrument Cluster																																V																									
T	2015	Trailblazer	Body	Trailer Interface Control Module																																V																									
T	2015	Trailblazer	Body	Radio																																																								
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																	V	V	V																						
T	2015	Trailblazer	Body	Parking Assist Control Module																																V																									
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																					
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																					
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																									
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module					V																																																				
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module				V	V																																																				
T	2016	Colorado (1GC)	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V							
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																V																									
T	2016	Colorado (1GC)	Body	Radio Controls																																																									
T	2016	Colorado (1GC)	Body	HVAC Controls																																																									
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																V																									
T	2016	Colorado (1GC)	Body	Radio																																																									
T	2016	Colorado (1GC)	Body	Amplifier																																																									
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																			
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V								
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V								
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																					
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																		
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																					
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																	V				
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																	V				
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																				V																													V				
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																	V				
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																					
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																		
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																					
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																					
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																					
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																					
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module				V	V																																																
T	2016	Colorado (MMM)	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																						V												
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
T	2016	Colorado (MMM)	Body	Instrument Cluster																																V																						
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																V																						
T	2016	Colorado (MMM)	Body	Radio																																																					
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																	V	V	V																			
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V								
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V								
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																V																						
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																					
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																		
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																					
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																					
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																				V																														V				
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																	V				
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																					
T	2016	S10	Powertrain	Transfer Case Control Module																																																					
T	2016	S10	Chassis	Electronic Brake Control Module																																																					
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																					
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module				V	V																																																
T	2016	S10	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																						V												
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
T	2016	S10	Body	Instrument Cluster																																V																						
T	2016	S10	Body	Trailer Interface Control Module																																V																						
T	2016	S10	Body	Radio																																																					
T	2016	S10	Body	Telematics Communication Interface Control Module																																	V	V	V																			
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V								
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V								
T	2016	S10	Body	Parking Assist Control Module																																V																						
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																		V				
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																		V				
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																				V																														V				
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																		V				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																								
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																								
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
T	2016	Trailblazer	Body	Body Control Module						V	V	V		V	V	V		V	V		V		V	V																							V													
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V	V																										
T	2016	Trailblazer	Body	Instrument Cluster																																V																								
T	2016	Trailblazer	Body	Trailer Interface Control Module																																V																								
T	2016	Trailblazer	Body	Radio																																																								
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																	V	V	V																				
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V									
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V									
T	2016	Trailblazer	Body	Parking Assist Control Module																																V																								
V	2009	ALL	Powertrain	Engine Control Module																																																								
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2009	ALL	Powertrain	Rear Drive System																																																								
V	2009	ALL	Powertrain	Transmission Control Module																																																								
V	2009	ALL	Chassis	Electronic Brake Control Module																																																								
V	2009	ALL	Body	Body Control Module																																																								
V	2009	ALL	Body	Digital Radio Receiver																																																								
V	2009	ALL	Body	Driver Door Switch																																																								
V	2009	ALL	Body	Heated Seat Module																																																								
V	2009	ALL	Body	HVAC Control Module Auto																																										V														
V	2009	ALL	Body	HVAC Control Module Manual																																										V														
V	2009	ALL	Body	Instrument Panel Cluster																																																								
V	2009	ALL	Body	Lift Gate Module																																																								
V	2009	ALL	Body	Park Assist Module																																																								
V	2009	ALL	Body	Passenger Door Switch																																																								
V	2009	ALL	Body	Passenger Presence System																																																								
V	2009	ALL	Body	Radio																																																								
V	2009	ALL	Body	Rear HVAC/RSA																																																								
V	2009	ALL	Body	Rollover Sensor																																																								
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2009	ALL	Body	Theft Deterrent Module																																																								
V	2010	ALL	Powertrain	Engine Control Module																																																								
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2010	ALL	Powertrain	Rear Drive System																																																								
V	2010	ALL	Powertrain	Transmission Control Module																																																								
V	2010	ALL	Chassis	Electronic Brake Control Module																																																								
V	2010	ALL	Body	Body Control Module																																																								
V	2010	ALL	Body	Digital Radio Receiver																																																								
V	2010	ALL	Body	Driver Door Switch																																																								
V	2010	ALL	Body	Heated Seat Module																																																								
V	2010	ALL	Body	HVAC Control Module Auto																																										V														
V	2010	ALL	Body	HVAC Control Module Manual																																										V														
V	2010	ALL	Body	Instrument Panel Cluster																																																								
V	2010	ALL	Body	Lift Gate Module																																																								
V	2010	ALL	Body	Park Assist Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
V	2010	ALL	Body	Passenger Door Switch																																																								
V	2010	ALL	Body	Passenger Presence System																																																								
V	2010	ALL	Body	Radio																																																								
V	2010	ALL	Body	Rear HVAC/RSA																																																								
V	2010	ALL	Body	Supplemental Inflatable Restraint																									V	V																														
V	2010	ALL	Body	Theft Deterrent Module																																																								
V	2011	ALL	Powertrain	Engine Control Module																																																								
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2011	ALL	Powertrain	Rear Drive System																																																								
V	2011	ALL	Powertrain	Transmission Control Module																																																								
V	2011	ALL	Chassis	Electronic Brake Control Module																																																								
V	2011	ALL	Body	Body Control Module																																																								
V	2011	ALL	Body	Digital Radio Receiver																																																								
V	2011	ALL	Body	Driver Door Switch																																																								
V	2011	ALL	Body	Heated Seat Module																																																								
V	2011	ALL	Body	HVAC Control Module Auto																																												V												
V	2011	ALL	Body	HVAC Control Module Manual																																												V												
V	2011	ALL	Body	Instrument Panel Cluster																																																								
V	2011	ALL	Body	Lift Gate Module																																																								
V	2011	ALL	Body	Park Assist Module																																																								
V	2011	ALL	Body	Passenger Door Switch																																																								
V	2011	ALL	Body	Passenger Presence System																																																								
V	2011	ALL	Body	Radio																																																								
V	2011	ALL	Body	Rear HVAC/RSA																																																								
V	2011	ALL	Body	Supplemental Inflatable Restraint																									V	V																														
V	2011	ALL	Body	Theft Deterrent Module																																																								
V	2012	ALL	Powertrain	Engine Control Module																				V																																				
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2012	ALL	Powertrain	Rear Drive System																																																								
V	2012	ALL	Powertrain	Transmission Control Module																																																								
V	2012	ALL	Chassis	Electronic Brake Control Module																																																								
V	2012	ALL	Body	Body Control Module																																																								
V	2012	ALL	Body	Digital Radio Receiver																																																								
V	2012	ALL	Body	Driver Door Switch																																																								
V	2012	ALL	Body	Heated Seat Module																																																								
V	2012	ALL	Body	HVAC Control Module Auto																																												V												
V	2012	ALL	Body	HVAC Control Module Manual																																												V												
V	2012	ALL	Body	Instrument Panel Cluster																																																								
V	2012	ALL	Body	Lift Gate Module																																																								
V	2012	ALL	Body	Park Assist Module																																																								
V	2012	ALL	Body	Passenger Door Switch																																																								
V	2012	ALL	Body	Passenger Presence System																																																								
V	2012	ALL	Body	Radio																																																								
V	2012	ALL	Body	Rear HVAC/RSA																																																								
V	2012	ALL	Body	Supplemental Inflatable Restraint																									V	V																														
V	2012	ALL	Body	Theft Deterrent Module																																																								
V	2013	ALL	Powertrain	Engine Control Module																				V																																				
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2013	ALL	Powertrain	Rear Drive System																																																								
V	2013	ALL	Powertrain	Transmission Control Module																																																								
V	2013	ALL	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
V	2013	ALL	Body	Body Control Module																																																								
V	2013	ALL	Body	Digital Radio Receiver																																																								
V	2013	ALL	Body	Driver Door Switch																																																								
V	2013	ALL	Body	Heated Seat Module																																																								
V	2013	ALL	Body	HVAC Control Module Auto																																											V													
V	2013	ALL	Body	HVAC Control Module Manual																																											V													
V	2013	ALL	Body	Instrument Panel Cluster																																																								
V	2013	ALL	Body	Left Side Object Detection Module																																																								
V	2013	ALL	Body	Lift Gate Module																																																								
V	2013	ALL	Body	Park Assist Module																																																								
V	2013	ALL	Body	Passenger Door Switch																																																								
V	2013	ALL	Body	Passenger Presence System																																																								
V	2013	ALL	Body	Radio																																																								
V	2013	ALL	Body	Rear HVAC/RSA																																																								
V	2013	ALL	Body	Right Side Object Detection Module																																																								
V	2013	ALL	Body	Supplemental Inflatable Restraint																									V	V																															
V	2013	ALL	Body	Theft Deterrent Module																																																								
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																					
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
V	2014	Traverse	Powertrain	Chassis Control Module																																																								
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																								
V	2014	Traverse	Chassis	Electronic Brake Control Module					V																																																			
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate						V	V	V						V					V	V																																					
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)						V	V	V						V					V	V																																					
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
V	2014	Traverse	Body	Passenger Presence Module																										V						V																									
V	2014	Traverse	Body	Instrument Cluster																																																								
V	2014	Traverse	Body	Radio																																																								
V	2014	Traverse	Body	Rear Audio Control Module																																																								
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																								
V	2014	Traverse	Body	Personal Audio Link Control Module																																																								
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																				
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																				
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																									V	V		V	V									
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																									V	V		V	V									
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																	V																																							
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																								
V	2014	Traverse	Body	Liftgate Control Module																																																								
V	2014	Traverse	Body	Seat Memory Control Module																																					V	V																		
V	2014	Traverse	Body	Front Seat Heating Control Module																																					V	V																		
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																								
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																								
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																								
V	2014	Traverse	Body	Parking Assist Control Module																																V																								
V	2014	Traverse	Body	Frontview Camera Module																																																								
V	2014	Traverse	Body	Theft Deterrent Module										V																																														
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																					
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																								
V	2015	Traverse	Chassis	Electronic Brake Control Module					V																																																			
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate						V	V	V						V					V	V																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)						V	V	V						V					V	V																																			
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																								
V	2015	Traverse	Body	Passenger Presence Module																										V						V																							
V	2015	Traverse	Body	Instrument Cluster																																																						
V	2015	Traverse	Body	Radio																																																						
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																						
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																		
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																									V	V		V	V								
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																									V	V		V	V								
V	2015	Traverse	Body	Liftgate Control Module																																																						
V	2015	Traverse	Body	Seat Memory Control Module																																					V	V																	
V	2015	Traverse	Body	Front Seat Heating Control Module																																					V	V																	
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																						
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																						
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																						
V	2015	Traverse	Body	Parking Assist Control Module																																V																							
V	2015	Traverse	Body	Frontview Camera Module																																																						
V	2015	Traverse	Body	Theft Deterrent Module										V																																												
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																			
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																						
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																						
V	2016	Traverse	Chassis	Electronic Brake Control Module					V																																																	
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate						V	V	V						V				V	V	V																																			
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)						V	V	V						V				V	V	V																																			
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																								
V	2016	Traverse	Body	Passenger Presence Module																										V						V																							
V	2016	Traverse	Body	Instrument Cluster																																																						
V	2016	Traverse	Body	Radio																																																						
V	2016	Traverse	Body	Rear Audio Control Module																																																						
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																						
V	2016	Traverse	Body	Personal Audio Link Control Module																																																						
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																	V	V	V																			
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																									V	V		V	V								
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																									V	V		V	V								
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																	V																																					
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																						
V	2016	Traverse	Body	Liftgate Control Module																																																						
V	2016	Traverse	Body	Seat Memory Control Module																																					V	V																	
V	2016	Traverse	Body	Front Seat Heating Control Module																																					V	V																	
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																						
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																						
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																						
V	2016	Traverse	Body	Parking Assist Control Module																																V																							
V	2016	Traverse	Body	Frontview Camera Module																																																						
V	2016	Traverse	Body	Theft Deterrent Module										V																																												
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																						
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																						
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																						
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																						
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																											
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																											
A	2011	Orlando	Chassis	Parking Brake Control Module																																																											
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2011	Orlando	Chassis	Power Steering Control Module	V	V	V																																																								
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module				V	V																																																						
A	2011	Orlando	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V																																				
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																												
A	2011	Orlando	Body	Instrument Cluster																																V																											
A	2011	Orlando	Body	Trailer Interface Control Module																																V																											
A	2011	Orlando	Body	Radio																																																										
A	2011	Orlando	Body	Multimedia Player Interface Module																																V																											
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																														V													V	V	V	V	V									
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																														V													V	V	V	V	V									
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																														V													V	V	V	V	V									
A	2011	Orlando	Body	Keyless Entry Control Module																																																										
A	2011	Orlando	Body	Parking Assist Control Module																																V																											
A	2011	Orlando	Body	Steering Column Lock Control Module																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																				V																																						
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																										
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2012	Orlando	Chassis	Parking Brake Control Module																																																										
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2012	Orlando	Chassis	Power Steering Control Module	V	V	V																																																								
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
A	2012	Orlando	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V		V	V	V	V	V		V	V																								V									
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
A	2012	Orlando	Body	Instrument Cluster																																V																											
A	2012	Orlando	Body	Trailer Interface Control Module																																V																											
A	2012	Orlando	Body	Radio																																																										
A	2012	Orlando	Body	Multimedia Player Interface Module																																V																											
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																					
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																														V													V	V	V	V	V									
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																														V													V	V	V	V	V									
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																														V													V	V	V	V	V									
A	2012	Orlando	Body	Keyless Entry Control Module																																																										
A	2012	Orlando	Body	Parking Assist Control Module																																V																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2012	Orlando	Body	Steering Column Lock Control Module																																																										
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																				V																																						
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																										
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2013	Orlando	Chassis	Parking Brake Control Module																																																										
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Orlando	Chassis	Power Steering Control Module	V	V	V																																																							
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
A	2013	Orlando	Body	Body Control Module						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																													V						
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
A	2013	Orlando	Body	Instrument Cluster																																V																										
A	2013	Orlando	Body	Radio																																																										
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2013	Orlando	Body	Multimedia Player Interface Module																																V																										
A	2013	Orlando	Body	Mobile Telephone Control Module																																V																										
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																						
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																							
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																														V														V	V	V	V	V										
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																														V														V	V	V	V											
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																														V														V	V	V	V	V										
A	2013	Orlando	Body	Front Seat Heating Control Module																																					V	V																				
A	2013	Orlando	Body	Keyless Entry Control Module																																																										
A	2013	Orlando	Body	Parking Assist Control Module																																V																										
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																						
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																						
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																				V																																						
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																				V																																						
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																				V																																				
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																								
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																								
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2014	Orlando	Chassis	Power Steering Control Module	V	V	V																																																					
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
A	2014	Orlando	Body	Body Control Module						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																											V						
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
A	2014	Orlando	Body	Instrument Cluster																																V																								
A	2014	Orlando	Body	Radio																																																								
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																								
A	2014	Orlando	Body	Multimedia Player Interface Module																																V																								
A	2014	Orlando	Body	Mobile Telephone Control Module																																V																								
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																					
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																						
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V										
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																														V												V	V	V	V											
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V										
A	2014	Orlando	Body	Front Seat Heating Control Module																																					V	V																			
A	2014	Orlando	Body	Rear Seat Heating Control Module																																						V	V																	
A	2014	Orlando	Body	Keyless Entry Control Module																																																								
A	2014	Orlando	Body	Parking Assist Control Module																																V																								
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																								
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																								
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																								
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																				V																																				
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																				V																																				
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																				V																																				
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																								
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																								
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2015	Orlando	Chassis	Power Steering Control Module	V	V	V																																																					
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
A	2015	Orlando	Body	Body Control Module						V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																											V						
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
A	2015	Orlando	Body	Instrument Cluster																																V																								
A	2015	Orlando	Body	Radio																																																								
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																								
A	2015	Orlando	Body	Mobile Telephone Control Module																																V																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																		V	V	V																				
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																														V											V	V	V	V	V										
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																														V											V	V	V	V											
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																														V											V	V	V	V	V										
A	2015	Orlando	Body	Front Seat Heating Control Module																																					V	V																	
A	2015	Orlando	Body	Rear Seat Heating Control Module																																							V	V															
A	2015	Orlando	Body	Keyless Entry Control Module																																																						
A	2015	Orlando	Body	Parking Assist Control Module																																V																							
A	2015	Orlando	Body	Frontview Camera Module																																																					
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																		
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																					
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																					
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																				
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																				
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																				
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																				
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																				
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																				
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																				V																																		
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																				
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																				
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																				
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																				
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																				V																																		
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																				
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																				
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																				
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																				
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																				
A	2016	Orlando	Chassis	Power Steering Control Module																																																				
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module				V	V																																																
A	2016	Orlando	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V					
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																						
A	2016	Orlando	Body	Instrument Cluster																																V																						
A	2016	Orlando	Body	Radio																																																				
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																				
A	2016	Orlando	Body	Multimedia Player Interface Module																																V																						
A	2016	Orlando	Body	Mobile Telephone Control Module																																V																						
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																		V	V	V																		
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																														V											V	V	V	V	V										
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																														V											V	V	V	V											
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																														V											V	V	V	V	V										
A	2016	Orlando	Body	Front Seat Heating Control Module																																					V	V																	
A	2016	Orlando	Body	Rear Seat Heating Control Module																																							V	V															
A	2016	Orlando	Body	Keyless Entry Control Module																																																					
A	2016	Orlando	Body	Parking Assist Control Module																																V																						
A	2016	Orlando	Body	Frontview Camera Module																																																					
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																																																					
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																																																					
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																																																					
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																																																									
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2009	N200	Chassis	Electronic Brake Control Module																																																										
C	2009	N200	Body	Supplemental Inflatable Restraint																																																										
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2009	N300	Chassis	Electronic Brake Control Module																																																										
C	2009	N300	Body	Supplemental Inflatable Restraint																																																										
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2010	N200	Chassis	Electronic Brake Control Module																																																										
C	2010	N200	Body	Supplemental Inflatable Restraint																																																										
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2010	N300	Chassis	Electronic Brake Control Module																																																										
C	2010	N300	Body	Supplemental Inflatable Restraint																																																										
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2011	N200	Chassis	Electronic Brake Control Module																																																										
C	2011	N200	Body	Supplemental Inflatable Restraint																																																										
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2011	N300	Chassis	Electronic Brake Control Module																																																										
C	2011	N300	Body	Supplemental Inflatable Restraint																																																										
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2012	N200	Chassis	Electronic Brake Control Module																																																										
C	2012	N200	Body	Supplemental Inflatable Restraint																																																										
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2012	N300	Chassis	Electronic Brake Control Module																																																										
C	2012	N300	Body	Supplemental Inflatable Restraint																																																										
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2013	N300	Chassis	Electronic Brake Control Module																																																										
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																																										
C	2014	N300	Chassis	Electronic Brake Control Module																																																										
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																																										
C	2015	Max	Chassis	Electronic Brake Control Module																																																										
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																																										
C	2015	Move	Chassis	Electronic Brake Control Module																																																										
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																																										
C	2015	N300	Chassis	Electronic Brake Control Module																																																										
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module																																																									
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																																									
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																																									
C	2016	Max	Chassis	Electronic Brake Control Module																																																									
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module																																																									
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																																									
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																																									
C	2016	Move	Chassis	Electronic Brake Control Module																																																									
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module																																																									
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																																									
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																																									
C	2016	N300	Chassis	Electronic Brake Control Module																																																									
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																									
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																									
M	2015	City Express	Chassis	Electronic Brake Control Module					V																																																				
M	2015	City Express	Chassis	Power Steering Control Module																																																									
M	2015	City Express	Body	Body Control Module															V		V		V																									V													
M	2015	City Express	Body	Underhood Fuse Block																																																								
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2015	City Express	Body	Instrument Cluster																																																									
M	2015	City Express	Body	Tire Pressure Indicator Module																								V																																	
M	2015	City Express	Body	Radio																																																								
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																									
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																									
M	2016	City Express	Chassis	Electronic Brake Control Module					V																																																				
M	2016	City Express	Chassis	Power Steering Control Module																																																									
M	2016	City Express	Body	Body Control Module															V		V		V																									V													
M	2016	City Express	Body	Underhood Fuse Block																																																								
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2016	City Express	Body	Instrument Cluster																																																									
M	2016	City Express	Body	Tire Pressure Indicator Module																								V																																	
M	2016	City Express	Body	Radio																																																								
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																									
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2011	Orlando	Chassis	Parking Brake Control Module																																																									
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2011	Orlando	Chassis	Power Steering Control Module	V	V	V																																																						
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2011	Orlando	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V																																
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
P	2011	Orlando	Body	Instrument Cluster																																V																							
P	2011	Orlando	Body	Trailer Interface Control Module																																V																							
P	2011	Orlando	Body	Radio																																																							
P	2011	Orlando	Body	Multimedia Player Interface Module																																V																							
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																														V												V	V	V	V	V								
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																														V												V	V	V	V	V								
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																														V												V	V	V	V	V								
P	2011	Orlando	Body	Keyless Entry Control Module																																																						
P	2011	Orlando	Body	Parking Assist Control Module																																V																							
P	2011	Orlando	Body	Steering Column Lock Control Module																																																						
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																						
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																						
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																						
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																						
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																						
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																						
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																						
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																						
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																						
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																				V																																			
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																						
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																						
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																						
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																																						
P	2012	Orlando	Chassis	Electronic Brake Control Module																																																						
P	2012	Orlando	Chassis	Parking Brake Control Module																																																						
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																						
P	2012	Orlando	Chassis	Power Steering Control Module	V	V	V																																																			
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
P	2012	Orlando	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V		V	V	V	V	V		V	V																							V							
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
P	2012	Orlando	Body	Instrument Cluster																																V																							
P	2012	Orlando	Body	Trailer Interface Control Module																																V																							
P	2012	Orlando	Body	Radio																																																						
P	2012	Orlando	Body	Multimedia Player Interface Module																																V																							
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																		
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																		
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																														V												V	V	V	V	V								
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																														V												V	V	V	V	V								
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																														V												V	V	V	V	V								
P	2012	Orlando	Body	Keyless Entry Control Module																																																					
P	2012	Orlando	Body	Parking Assist Control Module																																V																							
P	2012	Orlando	Body	Steering Column Lock Control Module																																																						
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																			
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																						
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																						
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																						
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																						
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																								
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																				V																																				
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																								
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																								
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																								
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																								
P	2013	Orlando	Chassis	Parking Brake Control Module																																																								
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2013	Orlando	Chassis	Power Steering Control Module	V	V	V																																																						
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
P	2013	Orlando	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V							
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
P	2013	Orlando	Body	Instrument Cluster																																	V																							
P	2013	Orlando	Body	Radio																																																								
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																								
P	2013	Orlando	Body	Multimedia Player Interface Module																																	V																							
P	2013	Orlando	Body	Mobile Telephone Control Module																																	V																							
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																			
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																														V											V	V	V	V	V									
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																														V											V	V	V	V										
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																														V											V	V	V	V	V									
P	2013	Orlando	Body	Front Seat Heating Control Module																																						V	V																
P	2013	Orlando	Body	Keyless Entry Control Module																																																								
P	2013	Orlando	Body	Parking Assist Control Module																																	V																							
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																				V																																				
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																				V																																				
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																				V																																				
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																				V																																				
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																								
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																								
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2014	Orlando	Chassis	Power Steering Control Module	V	V	V																																																								
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module				V	V																																																						
P	2014	Orlando	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V									
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
P	2014	Orlando	Body	Instrument Cluster																																V																										
P	2014	Orlando	Body	Radio																																																									
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																									
P	2014	Orlando	Body	Multimedia Player Interface Module																																V																									
P	2014	Orlando	Body	Mobile Telephone Control Module																																V																									
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V								
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																														V												V	V	V	V								
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V								
P	2014	Orlando	Body	Front Seat Heating Control Module																																					V	V																	
P	2014	Orlando	Body	Rear Seat Heating Control Module																																							V	V															
P	2014	Orlando	Body	Keyless Entry Control Module																																																								
P	2014	Orlando	Body	Parking Assist Control Module																																V																								
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																				
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																							
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																						
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																						
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																						
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																						
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																				V																																			
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																				V																																			
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																						
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																						
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																						
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																						
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																				V																																			
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																						
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																						
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																						
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																						
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																						
P	2015	Orlando	Chassis	Power Steering Control Module	V	V	V																																																						
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
P	2015	Orlando	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																								V									
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
P	2015	Orlando	Body	Instrument Cluster																																V																										
P	2015	Orlando	Body	Radio																																																								
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																								
P	2015	Orlando	Body	Mobile Telephone Control Module																																V																								
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																	V	V	V																				
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V								
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																														V												V	V	V	V								
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V								
P	2015	Orlando	Body	Front Seat Heating Control Module																																					V	V																	
P	2015	Orlando	Body	Rear Seat Heating Control Module																																							V	V															
P	2015	Orlando	Body	Keyless Entry Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
P	2015	Orlando	Body	Parking Assist Control Module																																	V																							
P	2015	Orlando	Body	Frontview Camera Module																																																							
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																				V																																			
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																						
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																						
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																						
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																						
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																						
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																						
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																						
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																						
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																				V																																			
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																						
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																						
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																						
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																						
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																				V																																			
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																						
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																						
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																						
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																						
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																						
P	2016	Orlando	Chassis	Power Steering Control Module																																																						
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
P	2016	Orlando	Body	Body Control Module						V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V																														
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
P	2016	Orlando	Body	Instrument Cluster																																	V																						
P	2016	Orlando	Body	Radio																																																						
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																						
P	2016	Orlando	Body	Multimedia Player Interface Module																																	V																						
P	2016	Orlando	Body	Mobile Telephone Control Module																																	V																						
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																		V	V	V																			
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																															V												V	V	V	V	V						
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																															V												V	V	V	V							
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																															V												V	V	V	V	V						
P	2016	Orlando	Body	Front Seat Heating Control Module																																					V	V																
P	2016	Orlando	Body	Rear Seat Heating Control Module																																							V	V														
P	2016	Orlando	Body	Keyless Entry Control Module																																																					
P	2016	Orlando	Body	Parking Assist Control Module																																	V																						
P	2016	Orlando	Body	Frontview Camera Module																																																						
U	2004	ALL	Powertrain	Engine Control Module																																																						
U	2004	ALL	Powertrain	Transmission Control Module																																																						
U	2004	ALL	Body	Digital Radio Receiver																																																						
U	2004	ALL	Body	Driver Information Center																																																						
U	2004	ALL	Body	Instrument Panel Cluster																																																						
U	2004	ALL	Body	Radio																																																						
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																						
U	2004	ALL	Body	Vehicle Theft Deterrent																																																						
U	2005	ALL	Powertrain	Engine Control Module																																																						
U	2005	ALL	Powertrain	Transmission Control Module																																																						
U	2005	ALL	Chassis	Electronic Brake Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
U	2005	ALL	Body	Body Control Module																																																									
U	2005	ALL	Body	Disc Player and Video																																																										
U	2005	ALL	Body	Digital Radio Receiver																																																										
U	2005	ALL	Body	HVAC Control Module																																												V													
U	2005	ALL	Body	Instrument Panel Cluster																																																										
U	2005	ALL	Body	Left Power Sliding Door Module																																																										
U	2005	ALL	Body	Mobile Digital Media																																																										
U	2005	ALL	Body	Navigation Radio																																																										
U	2005	ALL	Body	Navigation Radio																																																										
U	2005	ALL	Body	Radio																																																										
U	2005	ALL	Body	Right Power Sliding Door Module																																																										
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																										
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																										
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																										
U	2006	ALL	Chassis	Electronic Brake Control Module																																																										
U	2006	ALL	Body	Body Control Module																																																										
U	2006	ALL	Body	Disc Player and Video																																																										
U	2006	ALL	Body	Digital Radio Receiver																																																										
U	2006	ALL	Body	HVAC Control Module																																												V													
U	2006	ALL	Body	Instrument Panel Cluster																																																										
U	2006	ALL	Body	Left Power Sliding Door Module																																																										
U	2006	ALL	Body	Mobile Digital Media																																																										
U	2006	ALL	Body	Navigation Radio																																																										
U	2006	ALL	Body	Navigation Radio																																																										
U	2006	ALL	Body	Radio																																																										
U	2006	ALL	Body	Right Power Sliding Door Module																																																										
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																										
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
U	2007	ALL	Chassis	Electronic Brake Control Module																																																										
U	2007	ALL	Body	Body Control Module																																																										
U	2007	ALL	Body	Digital Radio Receiver																																																										
U	2007	ALL	Body	Disc Player and Video Display																																																										
U	2007	ALL	Body	HVAC Control Module																																												V													
U	2007	ALL	Body	Left Power Sliding Door Module																																																										
U	2007	ALL	Body	Mobile Digital Media																																																										
U	2007	ALL	Body	Radio																																																										
U	2007	ALL	Body	Navigation Radio																																																										
U	2007	ALL	Body	Right Power Sliding Door Module																																																										
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																										
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
U	2008	ALL	Chassis	Electronic Brake Control Module																																																										
U	2008	ALL	Body	Body Control Module																																																										
U	2008	ALL	Body	Digital Radio Receiver																																																										
U	2008	ALL	Body	Disc Player and Video Display																																																										
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																												V													

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																											V												
U	2008	ALL	Body	Left Power Sliding Door Module																																																						
U	2008	ALL	Body	Radio																																																						
U	2008	ALL	Body	Navigation Radio																																																						
U	2008	ALL	Body	Remote Control Door Lock Receiver																																																						
U	2008	ALL	Body	Right Power Sliding Door Module																																																						
U	2009	ALL	Powertrain	Engine Control Module																																																						
U	2009	ALL	Powertrain	Transmission Control Module																																																						
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																						
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																						
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																						
U	2009	ALL	Body	Body Control Module																																																						
U	2009	ALL	Body	Digital Radio Receiver																																																						
U	2009	ALL	Body	Disc Player and Video Display																																																						
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																											V												
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																											V												
U	2009	ALL	Body	Instrument Panel Cluster																																																						
U	2009	ALL	Body	Left Power Sliding Door Module																																																						
U	2009	ALL	Body	Radio																																																						
U	2009	ALL	Body	Remote Control Door Lock Receiver																																																						
U	2009	ALL	Body	Right Power Sliding Door Module																																																						
V	2004	ALL	Powertrain	Engine Data Display																																																						
V	2004	ALL	Powertrain	Transmission Data Display																																																						
V	2004	ALL	Body	Digital Radio Receiver																																																						
V	2004	ALL	Body	Driver Information Center																																																						
V	2004	ALL	Body	Instrument Panel Cluster																																																						
V	2004	ALL	Body	Radio																																																						
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																						
V	2004	ALL	Body	Vehicle Theft Deterrent																																																						
V	2005	Venture	Powertrain	Engine Control Module																																																						
V	2005	Venture	Powertrain	Transmission Control Module																																																						
V	2005	Venture	Body	Digital Radio Receiver																																																						
V	2005	Venture	Body	Driver Information Center																																																						
V	2005	Venture	Body	Instrument Panel Cluster																																																						
V	2005	Venture	Body	Radio																																																						
V	2005	Venture	Body	Supplemental Inflatable Restraint																																																						
V	2005	Venture	Body	Vehicle Theft Deterrent																																																						
V	2005	Uplander	Powertrain	Engine Control Module																																																						
V	2005	Uplander	Powertrain	Transmission Control Module																																																						
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																						
V	2005	Uplander	Body	Body Control Module																																																						
V	2005	Uplander	Body	Disc Player and Video																																																						
V	2005	Uplander	Body	Digital Radio Receiver																																																						
V	2005	Uplander	Body	HVAC Control Module																																											V												
V	2005	Uplander	Body	Instrument Panel Cluster																																																						
V	2005	Uplander	Body	Left Power Sliding Door Module																																																						
V	2005	Uplander	Body	Mobile Digital Media																																																						
V	2005	Uplander	Body	Navigation Radio																																																						
V	2005	Uplander	Body	Navigation Radio																																																						
V	2005	Uplander	Body	Radio																																																						
V	2005	Uplander	Body	Right Power Sliding Door Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
V	2005	Uplander	Body	Supplemental Inflatable Restraint																																																								
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																									
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																									
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																									
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																									
V	2006	ALL	Chassis	Electronic Brake Control Module																																																									
V	2006	ALL	Body	Body Control Module																																																								
V	2006	ALL	Body	Disc Player and Video																																																								
V	2006	ALL	Body	Digital Radio Receiver																																																								
V	2006	ALL	Body	HVAC Control Module																																												V												
V	2006	ALL	Body	Instrument Panel Cluster																																																								
V	2006	ALL	Body	Left Power Sliding Door Module																																																								
V	2006	ALL	Body	Mobile Digital Media																																																								
V	2006	ALL	Body	Navigation Radio																																																								
V	2006	ALL	Body	Navigation Radio																																																								
V	2006	ALL	Body	Radio																																																								
V	2006	ALL	Body	Right Power Sliding Door Module																																																								
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																								
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																								
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
V	2007	ALL	Chassis	Electronic Brake Control Module																																																								
V	2007	ALL	Body	Body Control Module																																																								
V	2007	ALL	Body	Digital Radio Receiver																																																								
V	2007	ALL	Body	Disc Player and Video Display																																																								
V	2007	ALL	Body	HVAC Control Module																																												V												
V	2007	ALL	Body	Left Power Sliding Door Module																																																								
V	2007	ALL	Body	Mobile Digital Media																																																								
V	2007	ALL	Body	Radio																																																								
V	2007	ALL	Body	Navigation Radio																																																								
V	2007	ALL	Body	Right Power Sliding Door Module																																																								
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																								
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																								
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
V	2008	ALL	Chassis	Electronic Brake Control Module																																																								
V	2008	ALL	Body	Body Control Module																																																								
V	2008	ALL	Body	Digital Radio Receiver																																																								
V	2008	ALL	Body	Disc Player and Video Display																																																								
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																												V												
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																												V												
V	2008	ALL	Body	Left Power Sliding Door Module																																																								
V	2008	ALL	Body	Radio																																																								
V	2008	ALL	Body	Navigation Radio																																																								
V	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
V	2008	ALL	Body	Right Power Sliding Door Module																																																								
V	2009	ALL	Powertrain	Engine Control Module																																																								
V	2009	ALL	Powertrain	Transmission Control Module																																																								
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																								
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																								
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
V	2009	ALL	Body	Body Control Module																																																									
V	2009	ALL	Body	Digital Radio Receiver																																																										
V	2009	ALL	Body	Disc Player and Video Display																																																										
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																												V													
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																												V													
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																										
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																										
V	2009	ALL	Body	Left Power Sliding Door Module																																																										
V	2009	ALL	Body	Radio																																																										
V	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
V	2009	ALL	Body	Right Power Sliding Door Module																																																										
X	2004	ALL	Powertrain	Engine Control Module																																																										
X	2004	ALL	Powertrain	Transmission Control Module																																																										
X	2004	ALL	Body	Digital Radio Receiver																																																										
X	2004	ALL	Body	Driver Information Center																																																										
X	2004	ALL	Body	Instrument Panel Cluster																																																										
X	2004	ALL	Body	Radio																																																										
X	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
X	2004	ALL	Body	Vehicle Theft Deterrent																																																										
X	2005	ALL	Powertrain	Engine Control Module																																																										
X	2005	ALL	Powertrain	Transmission Control Module																																																										
X	2005	ALL	Chassis	Electronic Brake Control Module																																																										
X	2005	ALL	Body	Body Control Module																																																										
X	2005	ALL	Body	Disc Player and Video																																																										
X	2005	ALL	Body	Digital Radio Receiver																																																										
X	2005	ALL	Body	HVAC Control Module																																												V													
X	2005	ALL	Body	Instrument Panel Cluster																																																										
X	2005	ALL	Body	Left Power Sliding Door Module																																																										
X	2005	ALL	Body	Mobile Digital Media																																																										
X	2005	ALL	Body	Navigation Radio																																																										
X	2005	ALL	Body	Navigation Radio																																																										
X	2005	ALL	Body	Radio																																																										
X	2005	ALL	Body	Right Power Sliding Door Module																																																										
X	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																										
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
X	2006	ALL	Chassis	Electronic Brake Control Module																																																										
X	2006	ALL	Body	Body Control Module																																																										
X	2006	ALL	Body	Disc Player and Video																																																										
X	2006	ALL	Body	Digital Radio Receiver																																																										
X	2006	ALL	Body	HVAC Control Module																																												V													
X	2006	ALL	Body	Instrument Panel Cluster																																																										
X	2006	ALL	Body	Left Power Sliding Door Module																																																										
X	2006	ALL	Body	Mobile Digital Media																																																										
X	2006	ALL	Body	Navigation Radio																																																										
X	2006	ALL	Body	Navigation Radio																																																										
X	2006	ALL	Body	Radio																																																										
X	2006	ALL	Body	Right Power Sliding Door Module																																																										

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
A	2016	Trax	Body	Frontview Camera Module																											V	V																													
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																									
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																									
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																									
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																									
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																									
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																									
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
C	2004	ALL	Chassis	ESC																																																								
C	2004	ALL	Chassis	Rear Wheel Steering																																																									
C	2004	ALL	Chassis	Tire Pressure Monitor																																																									
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																									
C	2004	ALL	Chassis	VSES																																																								
C	2004	ALL	Body	Amplifier (Bose)																																																									
C	2004	ALL	Body	Body Control Module																																																									
C	2004	ALL	Body	CD Changer																																																									
C	2004	ALL	Body	Chime																																																									
C	2004	ALL	Body	Driver Door Module																																																									
C	2004	ALL	Body	Driver Seat Module																																																									
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																									
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																									
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
C	2004	ALL	Body	Instrument Panel Cluster																																																									

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module				V		V																																																						
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																												
C	2010	Silverado Hybrid	Body	Body Control Module																																																												
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																												
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																												
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																												
C	2010	Silverado Hybrid	Body	HVAC Control Module																																																												
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
C	2010	Silverado Hybrid	Body	Park Assist Module																																																												
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																												
C	2010	Silverado Hybrid	Body	Passenger Presence System																																																												
C	2010	Silverado Hybrid	Body	Radio																																																												
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																												
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Tahoe	Body	Amplifier (Bose)																																																												
C	2010	Tahoe	Body	Assist Step Controller																																																												
C	2010	Tahoe	Body	Body Control Module																																																												
C	2010	Tahoe	Body	Body Control Module (aux.)																																																												
C	2010	Tahoe	Body	Digital Radio Receiver																																																												
C	2010	Tahoe	Body	Driver Door Switch																																																												
C	2010	Tahoe	Body	HVAC Control Module Auto																																																												
C	2010	Tahoe	Body	HVAC Control Module Manual																																																												
C	2010	Tahoe	Body	Instrument Panel Cluster																																																												
C	2010	Tahoe	Body	Left Side Object Detection Module																																																												
C	2010	Tahoe	Body	Lift Gate Module																																																												
C	2010	Tahoe	Body	Memory Seat Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																																												
C	2011	Silverado	Body	Theft Deterrent Module																																																												
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module				V		V																																																				
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																											
C	2011	Silverado Hybrid	Body	Body Control Module																																																											
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																											
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																											
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																											
C	2011	Silverado Hybrid	Body	HVAC Control Module																																																											
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
C	2011	Silverado Hybrid	Body	Park Assist Module																																																											
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2011	Silverado Hybrid	Body	Passenger Presence System																																																											
C	2011	Silverado Hybrid	Body	Radio																																																											
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2011	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2011	Tahoe	Body	Amplifier (Bose)																																																											
C	2011	Tahoe	Body	Assist Step Controller																																																											
C	2011	Tahoe	Body	Body Control Module																																																											
C	2011	Tahoe	Body	Body Control Module (aux.)																																																											
C	2011	Tahoe	Body	Digital Radio Receiver																																																											
C	2011	Tahoe	Body	Driver Door Switch																																																											
C	2011	Tahoe	Body	HVAC Control Module Auto																																																											
C	2011	Tahoe	Body	HVAC Control Module Manual																																																											
C	2011	Tahoe	Body	Instrument Panel Cluster																																																											
C	2011	Tahoe	Body	Left Side Object Detection Module																																																											
C	2011	Tahoe	Body	Lift Gate Module																																																											
C	2011	Tahoe	Body	Memory Seat Module																																																											
C	2011	Tahoe	Body	Park Assist Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2012	Avalanche	Body	Amplifier (Bose)																																																														
C	2012	Avalanche	Body	Assist Step Controller																																																														
C	2012	Avalanche	Body	Body Control Module																																																														
C	2012	Avalanche	Body	Body Control Module (aux.)																																																														
C	2012	Avalanche	Body	Digital Radio Receiver																																																														
C	2012	Avalanche	Body	Driver Door Switch																																																														
C	2012	Avalanche	Body	HVAC Control Module Auto																																																														
C	2012	Avalanche	Body	HVAC Control Module Manual																																																														
C	2012	Avalanche	Body	Instrument Panel Cluster																																																														
C	2012	Avalanche	Body	Memory Seat Module																																																														
C	2012	Avalanche	Body	Navigation Radio																																																														
C	2012	Avalanche	Body	Park Assist Module																																																														
C	2012	Avalanche	Body	Passenger Door Switch																																																														
C	2012	Avalanche	Body	Passenger Presence System																																																														
C	2012	Avalanche	Body	Radio																																																														
C	2012	Avalanche	Body	Rear Heated Seat Module																																																														
C	2012	Avalanche	Body	Rear HVAC/RSA																																																														
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																														
C	2012	Avalanche	Body	Theft Deterrent Module																																																														
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																														
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																														
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																														
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																														
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																														
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																														
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																														
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																														
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																														
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																														
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																														
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																														
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																														
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																														
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																														
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																														
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																														
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																														
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																														
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																														
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																														
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																														
C	2012	Captiva	Chassis	Parking Brake Control Module																																																														
C	2012	Captiva	Body	Body Control Module		V															V																					V																									
C	2012	Captiva	Body	Auxiliary Body Control Module																																																														
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2012	Captiva	Body	Instrument Cluster																																																														
C	2012	Captiva	Body	Headlamp Control Module																															V																															
C	2012	Captiva	Body	HVAC Control Module																																																														
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																														
C	2012	Captiva	Body	Parking Assist Control Module																																																														

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																											
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto		V															V																					V																				
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual		V															V																					V																				
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Captiva (Other)	Body	Instrument Cluster																																																											
C	2014	Captiva (Other)	Body	Headlamp Control Module																															V																													
C	2014	Captiva (Other)	Body	HVAC Control Module																																																											
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
C	2014	Captiva (Other)	Body	Theft Deterrent Module																																																											
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2014	Cheyenne	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																													
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																												
C	2014	Cheyenne	Chassis	Power Steering Control Module																			V													V																												
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2014	Cheyenne	Body	Body Control Module																	V																																										
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Cheyenne	Body	Passenger Presence Module																																																											
C	2014	Cheyenne	Body	Instrument Cluster																																																											
C	2014	Cheyenne	Body	Radio Control																																																											
C	2014	Cheyenne	Body	HVAC Control																																																											
C	2014	Cheyenne	Body	Radio																		V	V																																								
C	2014	Cheyenne	Body	Amplifier																				V	V																																						
C	2014	Cheyenne	Body	Media Disc Player																																																											
C	2014	Cheyenne	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																											
C	2014	Cheyenne	Body	HVAC Control Module																																																											
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																											
C	2014	Cheyenne	Body	Parking Assist Control Module																																																											
C	2014	Cheyenne	Body	Frontview Camera Module																											V	V																															
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																												
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2014	Silverado	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																														
C	2014	Silverado	Chassis	Parking Brake Control Module																																																													
C	2014	Silverado	Chassis	Power Steering Control Module																			V														V																											
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2014	Silverado	Body	Body Control Module																	V																																										
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Silverado	Body	Passenger Presence Module																																																												
C	2014	Silverado	Body	Instrument Cluster																																																												
C	2014	Silverado	Body	Radio Control																																																											
C	2014	Silverado	Body	HVAC Control																																																											
C	2014	Silverado	Body	Radio																		V	V																																								
C	2014	Silverado	Body	Amplifier																				V	V																																						
C	2014	Silverado	Body	Media Disc Player																																																											
C	2014	Silverado	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																	
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																											
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
C	2014	Silverado	Body	Parking Assist Control Module																																																											
C	2014	Silverado	Body	Frontview Camera Module																											V	V																														
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																											
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																											
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																											
C	2014	Silverado HD	Chassis	Electronic Brake Control Module											V	V	V	V																																													
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																											
C	2014	Silverado HD	Chassis	Suspension Control Module																																																											
C	2014	Silverado HD	Body	Body Control Module		V															V																					V																					
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Silverado HD	Body	Passenger Presence Module																																																											
C	2014	Silverado HD	Body	Instrument Cluster																																																											
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																											
C	2014	Silverado HD	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2014	Silverado HD	Body	Navigation Radio																																																												
C	2014	Silverado HD	Body	Uplevel Radio																																																												
C	2014	Silverado HD	Body	Amplifier																																																												
C	2014	Silverado HD	Body	Rear Audio Control Module																																																												
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																												
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																												
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																												
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																												
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																												
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																												
C	2014	Silverado HD	Body	Seat Memory Control Module																																																												
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																												
C	2014	Silverado HD	Body	Parking Assist Control Module																																																												
C	2014	Silverado HD	Body	Theft Deterrent Module																																																												
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																												
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																												
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																												
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																												
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2014	Suburban	Chassis	Electronic Brake Control Module										V	V	V	V	V																																														
C	2014	Suburban	Chassis	Parking Brake Control Module																																																												
C	2014	Suburban	Chassis	Suspension Control Module																																														V														
C	2014	Suburban	Body	Body Control Module		V															V																					V																						
C	2014	Suburban	Body	Auxiliary Body Control Module																																																												
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Suburban	Body	Passenger Presence Module																																																												
C	2014	Suburban	Body	Instrument Cluster																																																												
C	2014	Suburban	Body	Base Radio																																																												
C	2014	Suburban	Body	Navigation Radio																																																												
C	2014	Suburban	Body	Uplevel Radio																																																												
C	2014	Suburban	Body	Amplifier																																																												
C	2014	Suburban	Body	Rear Audio Control Module																																																												
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																												
C	2014	Suburban	Body	Personal Audio Link Control Module																																																												
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																												
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																												
C	2014	Suburban	Body	Liftgate Control Module																																																												
C	2014	Suburban	Body	Seat Memory Control Module																																																												
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Silverado	Chassis	Suspension Control Module																																												V													
C	2015	Silverado	Body	Body Control Module																																																									
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	Silverado	Body	Passenger Presence Module																																																									
C	2015	Silverado	Body	Instrument Cluster																																																									
C	2015	Silverado	Body	Radio Controls																																																									
C	2015	Silverado	Body	HVAC Controls																																																									
C	2015	Silverado	Body	Radio																		V	V																																							
C	2015	Silverado	Body	Amplifier																				V	V																																					
C	2015	Silverado	Body	Media Disc Player																																																									
C	2015	Silverado	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																									
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																									
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																									
C	2015	Silverado	Body	Parking Assist Control Module																																																									
C	2015	Silverado	Body	Frontview Camera Module																											V	V																														
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																									
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																												V													
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																									
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2015	Suburban	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																											
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																V																																									
C	2015	Suburban	Chassis	Parking Brake Control Module																																																									
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																									
C	2015	Suburban	Chassis	Power Steering Control Module																			V														V																								
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2015	Suburban	Chassis	Suspension Control Module																																												V													
C	2015	Suburban	Body	Body Control Module																	V																																								
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	Suburban	Body	Passenger Presence Module																																																									
C	2015	Suburban	Body	Instrument Cluster																																																									
C	2015	Suburban	Body	Radio Controls																																																								
C	2015	Suburban	Body	HVAC Controls																																																								
C	2015	Suburban	Body	Radio																		V	V																																						
C	2015	Suburban	Body	Amplifier																				V	V																																			
C	2015	Suburban	Body	Media Disc Player																																																								
C	2015	Suburban	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																															
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																								
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																								
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2015	Suburban	Body	HVAC Control Module																																																								
C	2015	Suburban	Body	Liftgate Control Module																																																								
C	2015	Suburban	Body	Keyless Entry Control Module																																																								

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																														
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																														
C	2016	Captiva (3GN)	Body	Body Control Module		V															V																					V																							
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																														
C	2016	Captiva (3GN)	Body	Radio																																																														
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																														
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																														
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																														
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																														
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																														
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																														
C	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																														
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																														
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																														
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																														
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																															V																															
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																															V																															
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																														
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																															V																															
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																															V																															
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																														
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																													
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																													
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																														
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																													
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																													
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																														
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																														
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																														
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																														
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																														
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto		V															V																					V																							
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual		V															V																					V																							
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																														
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Captiva (Other)	Body	Instrument Cluster																																																														
C	2016	Captiva (Other)	Body	Headlamp Control Module																															V																															
C	2016	Captiva (Other)	Body	Radio																																																														
C	2016	Captiva (Other)	Body	HVAC Control Module																																																														
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																														
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																														
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																														
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																														
C	2016	Captiva (Other)	Body	Theft Deterrent Module																																																														
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																														
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																														
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																														
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																														

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																													
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																													
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																													
G	2006	Express/Savana	Chassis	VSES																																																													
G	2006	Express/Savana	Body	Body Control Module																																																													
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																													
G	2006	Express/Savana	Body	Passenger Presence System																																																													
G	2006	Express/Savana	Body	Base Radio																																																													
G	2006	Express/Savana	Body	Uplevel Radio																																																													
G	2006	Express/Savana	Body	Remote Function Actuation																																																													
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																													
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																													
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																													
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																													
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																													
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																													
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																													
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																													
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																													
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																													
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																													
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																													
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																													
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																													
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																													
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																													
G	2006	Express Access/Savana Pro	Chassis	VSES																																																													
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																													
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																													
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																													
G	2006	Express Access/Savana Pro	Body	Base Radio																																																													
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																													
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																													
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module								V																																																			
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2011	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																											
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2011	Express Access/Savana Pro	Body	Radio																																																											
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module								V																																																			
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2012	Express/Savana	Body	Body Control Module																																																											
G	2012	Express/Savana	Body	Digital Radio Receiver																																																											
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2012	Express/Savana	Body	Passenger Presence System																																																											
G	2012	Express/Savana	Body	Radio																																																											
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2012	Express/Savana	Body	Rollover Sensor																																																											
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2012	Express/Savana	Body	Theft Deterrent Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module								V																																																			
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2013	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																												
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																												
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2013	Express Access/Savana Pro	Body	Radio																																																												
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																												
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
G	2014	Express	Chassis	Electronic Brake Control Module											V	V	V	V																																														
G	2014	Express	Body	Body Control Module		V															V																					V																						
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2014	Express	Body	Passenger Presence Module																																																												
G	2014	Express	Body	Rollover Sensor Module																																																												
G	2014	Express	Body	Instrument Cluster																																																											
G	2014	Express	Body	Chime Alarm Control Module																																																											
G	2014	Express	Body	Base Radio																																																										
G	2014	Express	Body	Navigation Radio																																																										
G	2014	Express	Body	Uplevel Radio																																																										
G	2014	Express	Body	Digital Radio Receiver Control Module																																																										
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2014	Express	Body	Auxiliary Heater Control Module		V																																																								
G	2014	Express	Body	Remote Control Door Lock Receiver																																																										
G	2014	Express	Body	Parking Assist Control Module																																																										
G	2014	Express	Body	Theft Deterrent Module																																																										

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																														
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																														
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																														
G	2016	Savana	Chassis	Electronic Brake Control Module											V	V	V	V																																															
G	2016	Savana	Body	Body Control Module		V															V																					V																							
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
G	2016	Savana	Body	Instrument Cluster																																																													
G	2016	Savana	Body	Chime Alarm Control Module																																																													
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																												
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																												
G	2016	Savana	Body	Auxiliary Heater Control Module		V																																																										
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																												
G	2016	Savana	Body	Parking Assist Control Module																																																											
G	2016	Savana	Body	Theft Deterrent Module																																																											
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																											
H	2004	Express/Savana	Chassis	VSES																																																										
H	2004	Express/Savana	Body	Body Control Module																																																										
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2004	Express/Savana	Body	OnStar																																																									
H	2004	Express/Savana	Body	Base Radio																																																									
H	2004	Express/Savana	Body	Uplevel Radio																																																									
H	2004	Express/Savana	Body	Remote Function Actuation																																																									
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
H	2004	Express Access/Savana Pro	Chassis	VSES																																																									
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2004	Express Access/Savana Pro	Body	OnStar																																																									
H	2004	Express Access/Savana Pro	Body	Base Radio																																																									
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2005	Express/Savana	Chassis	VSES																																																									
H	2005	Express/Savana	Body	Body Control Module																																																									
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2005	Express/Savana	Body	Base Radio																																																									
H	2005	Express/Savana	Body	Uplevel Radio																																																									
H	2005	Express/Savana	Body	Remote Function Actuation																																																									
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																									

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																													
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
H	2010	Express/Savana	Body	Body Control Module																																																													
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																													
H	2010	Express/Savana	Body	Passenger Presence System																																																													
H	2010	Express/Savana	Body	Radio																																																												
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
H	2010	Express/Savana	Body	Rollover Sensor																																																													
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
H	2010	Express/Savana	Body	Theft Deterrent Module																																																													
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																													
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																													
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																													
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																													
H	2010	Express Access/Savana Pro	Body	Radio																																																													
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																													
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																													
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																													
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																													
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																													
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
H	2011	Express/Savana	Body	Body Control Module																																																													
H	2011	Express/Savana	Body	Digital Radio Receiver																																																													
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																													
H	2011	Express/Savana	Body	Passenger Presence System																																																													

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2014	Savana	Chassis	Electronic Brake Control Module											V	V	V	V																																												
H	2014	Savana	Body	Body Control Module		V															V																					V																			
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Savana	Body	Passenger Presence Module																																																										
H	2014	Savana	Body	Rollover Sensor Module																																																									
H	2014	Savana	Body	Instrument Cluster																																																									
H	2014	Savana	Body	Chime Alarm Control Module																																																									
H	2014	Savana	Body	Base Radio																																																									
H	2014	Savana	Body	Navigation Radio																																																									
H	2014	Savana	Body	Uplevel Radio																																																									
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																									
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																									
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																									
H	2014	Savana	Body	Auxiliary Heater Control Module		V																																																							
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																									
H	2014	Savana	Body	Parking Assist Control Module																																																									
H	2014	Savana	Body	Theft Deterrent Module																																																									
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2015	Express	Chassis	Electronic Brake Control Module											V	V	V	V																																												
H	2015	Express	Body	Body Control Module		V															V																					V																			
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
H	2015	Express	Body	Rollover Sensor Module																																																									
H	2015	Express	Body	Instrument Cluster																																																									
H	2015	Express	Body	Digital Radio Receiver Control Module																																																									
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																									
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																									
H	2015	Express	Body	Auxiliary Heater Control Module		V																																																							
H	2015	Express	Body	Remote Control Door Lock Receiver																																																									
H	2015	Express	Body	Parking Assist Control Module																																																									
H	2015	Express	Body	Theft Deterrent Module																																																									
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2015	Savana	Chassis	Electronic Brake Control Module											V	V	V	V																																												
H	2015	Savana	Body	Body Control Module		V															V																					V																			
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																												
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																													
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																													
J	2014	Trax	Chassis	Electronic Brake Control Module																																																													
J	2014	Trax	Chassis	Power Steering Control Module																																V																													
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Trax	Body	Body Control Module																																	V	V																								
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Trax	Body	Passenger Presence Module																																																												
J	2014	Trax	Body	Instrument Cluster																																																												
J	2014	Trax	Body	Radio																																																												
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Trax	Body	Front Seat Heating Control Module																																																												
J	2014	Trax	Body	Parking Assist Control Module																																							V	V	V																	
J	2014	Trax	Body	Frontview Camera Module																											V																															
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																												
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																												
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																												
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																												
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																												
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																												
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																												
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																												
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																												
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																												
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																											
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																											
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																											
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																											
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																											
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																											
J	2016	Trax	Powertrain	Chassis Control Module																																																											
J	2016	Trax	Chassis	Electronic Brake Control Module																																																											
J	2016	Trax	Chassis	Power Steering Control Module																																	V																										
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Trax	Body	Body Control Module									V																									V	V																								
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Trax	Body	Passenger Presence Module																																																											
J	2016	Trax	Body	Instrument Cluster																																																											
J	2016	Trax	Body	Trailer Interface Control Module																																																											
J	2016	Trax	Body	Radio																																																											
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																											
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																											
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Trax	Body	Seat Memory Control Module																																																											
J	2016	Trax	Body	Front Seat Heating Control Module																																																											
J	2016	Trax	Body	Right Side Object Detection Control Module																																																											
J	2016	Trax	Body	Left Side Object Detection Control Module																																																											
J	2016	Trax	Body	Parking Assist Control Module																																																											
J	2016	Trax	Body	Frontview Camera Module																											V	V																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																											
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																											
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																											
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																											
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2008	Suburban	Body	Radio																																																												
K	2008	Suburban	Body	Rear Heated Seat Module																																																												
K	2008	Suburban	Body	Rear HVAC/RSA																																																												
K	2008	Suburban	Body	Rollover Sensor																																																												
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2008	Suburban	Body	Theft Deterrent Module																																																												
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2008	Silverado	Chassis	Electronic Suspension Control																																																												
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																												
K	2008	Silverado	Body	Amplifier (Bose)																																																												
K	2008	Silverado	Body	Body Control Module																																																												
K	2008	Silverado	Body	Body Control Module (aux.)																																																												
K	2008	Silverado	Body	Digital Radio Receiver																																																												
K	2008	Silverado	Body	Driver Door Switch																																																												
K	2008	Silverado	Body	HVAC Control Module Auto																																																												
K	2008	Silverado	Body	HVAC Control Module Manual																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																											
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Cheyenne	Body	Amplifier (Bose)																																																											
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2010	Cheyenne	Body	Digital Radio Receiver																																																											
K	2010	Cheyenne	Body	Driver Door Switch																																																											
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2010	Cheyenne	Body	Park Assist Module																																																											
K	2010	Cheyenne	Body	Passenger Door Switch																																																											
K	2010	Cheyenne	Body	Passenger Presence System																																																											
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																											
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
K	2010	Cheyenne	Body	Theft Deterrent Module																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																											
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2010	Suburban	Chassis	Electronic Suspension Control																																																											
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Suburban	Body	Amplifier (Bose)																																																											
K	2010	Suburban	Body	Assist Step Controller																																																											
K	2010	Suburban	Body	Body Control Module																																																											
K	2010	Suburban	Body	Body Control Module (aux.)																																																											
K	2010	Suburban	Body	Digital Radio Receiver																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																													
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																													
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																													
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																													
K	2011	Cheyenne	Body	Amplifier (Bose)																																																													
K	2011	Cheyenne	Body	Body Control Module																																																													
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																													
K	2011	Cheyenne	Body	Digital Radio Receiver																																																													
K	2011	Cheyenne	Body	Driver Door Switch																																																													
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																													
K	2011	Cheyenne	Body	Park Assist Module																																																													
K	2011	Cheyenne	Body	Passenger Door Switch																																																													
K	2011	Cheyenne	Body	Passenger Presence System																																																													
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																													
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																													
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																													
K	2011	Cheyenne	Body	Theft Deterrent Module																																																													
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																													
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																													
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																													
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																													
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																													
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
K	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																													
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2011	Suburban	Chassis	Electronic Suspension Control																																																													
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																													
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																													
K	2011	Suburban	Body	Amplifier (Bose)																																																													
K	2011	Suburban	Body	Assist Step Controller																																																													
K	2011	Suburban	Body	Body Control Module																																																													
K	2011	Suburban	Body	Body Control Module (aux.)																																																													
K	2011	Suburban	Body	Digital Radio Receiver																																																													
K	2011	Suburban	Body	Driver Door Switch																																																													
K	2011	Suburban	Body	HVAC Control Module Auto																																																													
K	2011	Suburban	Body	HVAC Control Module Manual																																																													

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2011	Silverado	Chassis	Electronic Suspension Control																																																													
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2011	Silverado	Body	Amplifier (Bose)																																																												
K	2011	Silverado	Body	Body Control Module																																																												
K	2011	Silverado	Body	Body Control Module (aux.)																																																												
K	2011	Silverado	Body	Digital Radio Receiver																																																												
K	2011	Silverado	Body	Driver Door Switch																																																												
K	2011	Silverado	Body	HVAC Control Module Auto																																																												
K	2011	Silverado	Body	HVAC Control Module Manual																																																												
K	2011	Silverado	Body	Instrument Panel Cluster																																																												
K	2011	Silverado	Body	Memory Seat Module																																																												
K	2011	Silverado	Body	Park Assist Module																																																												
K	2011	Silverado	Body	Passenger Door Switch																																																												
K	2011	Silverado	Body	Passenger Presence System																																																												
K	2011	Silverado	Body	Radio																																																												
K	2011	Silverado	Body	Rear Heated Seat Module																																																												
K	2011	Silverado	Body	Rear HVAC/RSA																																																												
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2011	Silverado	Body	Theft Deterrent Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module				V		V																																																					
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2011	Silverado Hybrid	Body	Body Control Module																																																												
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																												
K	2011	Silverado Hybrid	Body	HVAC Control Module																																																												
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2011	Silverado Hybrid	Body	Park Assist Module																																																												
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2011	Silverado Hybrid	Body	Passenger Presence System																																																												
K	2011	Silverado Hybrid	Body	Radio																																																												
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																													
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																																												
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																												
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																																											
K	2011	Tahoe Hybrid	Body	Radio																																																											
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2012	Avalanche	Chassis	Electronic Brake Control Module																																																											
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Avalanche	Body	Amplifier (Bose)																																																											
K	2012	Avalanche	Body	Assist Step Controller																																																											
K	2012	Avalanche	Body	Body Control Module																																																											
K	2012	Avalanche	Body	Body Control Module (aux.)																																																											
K	2012	Avalanche	Body	Digital Radio Receiver																																																											
K	2012	Avalanche	Body	Driver Door Switch																																																											
K	2012	Avalanche	Body	HVAC Control Module Auto																																																											
K	2012	Avalanche	Body	HVAC Control Module Manual																																																											
K	2012	Avalanche	Body	Instrument Panel Cluster																																																											
K	2012	Avalanche	Body	Memory Seat Module																																																											
K	2012	Avalanche	Body	Navigation Radio																																																											
K	2012	Avalanche	Body	Park Assist Module																																																											
K	2012	Avalanche	Body	Passenger Door Switch																																																											
K	2012	Avalanche	Body	Passenger Presence System																																																											
K	2012	Avalanche	Body	Radio																																																											
K	2012	Avalanche	Body	Rear Heated Seat Module																																																											
K	2012	Avalanche	Body	Rear HVAC/RSA																																																											
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2012	Avalanche	Body	Theft Deterrent Module																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																														
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																														
K	2013	Tahoe Hybrid	Body	Body Control Module																																																														
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																														
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																														
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																														
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																														
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																																														
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																														
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																														
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																																														
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																														
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																														
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																														
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																																														
K	2013	Tahoe Hybrid	Body	Radio																																																														
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																														
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																														
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																														
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																														
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																														
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																														
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																														
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																														
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																														
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																														
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																														
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																														
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																														
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																														
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																														
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
K	2014	Cheyenne	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																															
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																															
K	2014	Cheyenne	Chassis	Power Steering Control Module																			V														V																												
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																														
K	2014	Cheyenne	Body	Body Control Module																	V																																												
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
K	2014	Cheyenne	Body	Passenger Presence Module																																																														
K	2014	Cheyenne	Body	Instrument Cluster																																																														
K	2014	Cheyenne	Body	Radio Control																																																														
K	2014	Cheyenne	Body	HVAC Control																																																														
K	2014	Cheyenne	Body	Radio																		V	V																																									
K	2014	Cheyenne	Body	Amplifier																				V	V																																								
K	2014	Cheyenne	Body	Media Disc Player																																																														
K	2014	Cheyenne	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																			
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																														

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2014	Cheyenne	Body	HVAC Control Module																																																												
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																												
K	2014	Cheyenne	Body	Parking Assist Control Module																																																												
K	2014	Cheyenne	Body	Frontview Camera Module																											V	V																																
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2014	Silverado	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																													
K	2014	Silverado	Chassis	Parking Brake Control Module																																																												
K	2014	Silverado	Chassis	Power Steering Control Module																			V														V																										
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2014	Silverado	Body	Body Control Module																	V																																										
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Silverado	Body	Passenger Presence Module																																																												
K	2014	Silverado	Body	Instrument Cluster																																																												
K	2014	Silverado	Body	Radio Control																																																											
K	2014	Silverado	Body	HVAC Control																																																											
K	2014	Silverado	Body	Radio																		V	V																																								
K	2014	Silverado	Body	Amplifier																				V	V																																						
K	2014	Silverado	Body	Media Disc Player																																																											
K	2014	Silverado	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																	
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																											
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
K	2014	Silverado	Body	Parking Assist Control Module																																																											
K	2014	Silverado	Body	Frontview Camera Module																											V	V																																
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																											
K	2014	Silverado HD	Chassis	Electronic Brake Control Module											V	V	V	V																																												
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2014	Silverado HD	Chassis	Suspension Control Module																																												V												
K	2014	Silverado HD	Body	Body Control Module		V															V																				V																		
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
K	2014	Silverado HD	Body	Passenger Presence Module																																																						
K	2014	Silverado HD	Body	Instrument Cluster																																																						
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																						
K	2014	Silverado HD	Body	Base Radio																																																						
K	2014	Silverado HD	Body	Navigation Radio																																																						
K	2014	Silverado HD	Body	Uplevel Radio																																																						
K	2014	Silverado HD	Body	Amplifier																																																						
K	2014	Silverado HD	Body	Rear Audio Control Module																																																						
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																						
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																						
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																						
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																						
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																						
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																						
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																						
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																						
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																						
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																						
K	2014	Silverado HD	Body	Seat Memory Control Module																																																						
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																						
K	2014	Silverado HD	Body	Parking Assist Control Module																																																						
K	2014	Silverado HD	Body	Theft Deterrent Module																																																						
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																						
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																						
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																						
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																						
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																						
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																						
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																						
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																						
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																						
K	2014	Suburban	Chassis	Electronic Brake Control Module											V	V	V	V	V																																								
K	2014	Suburban	Chassis	Parking Brake Control Module																																																						
K	2014	Suburban	Chassis	Suspension Control Module																																												V												
K	2014	Suburban	Body	Body Control Module		V															V																				V																		
K	2014	Suburban	Body	Auxiliary Body Control Module																																																						
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
K	2014	Suburban	Body	Passenger Presence Module																																																						
K	2014	Suburban	Body	Instrument Cluster																																																						
K	2014	Suburban	Body	Base Radio																																																						
K	2014	Suburban	Body	Navigation Radio																																																						
K	2014	Suburban	Body	Uplevel Radio																																																						
K	2014	Suburban	Body	Amplifier																																																						
K	2014	Suburban	Body	Rear Audio Control Module																																																						
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																						
K	2014	Suburban	Body	Personal Audio Link Control Module																																																						
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																						
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																						

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																												
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																												
K	2014	Suburban	Body	Liftgate Control Module																																																												
K	2014	Suburban	Body	Seat Memory Control Module																																																												
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																												
K	2014	Suburban	Body	Assist Step Control Module																																																												
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																												
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																												
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																												
K	2014	Suburban	Body	Parking Assist Control Module																																																												
K	2014	Suburban	Body	Theft Deterrent Module																																																												
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																												
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2014	Tahoe	Chassis	Electronic Brake Control Module											V	V	V	V	V																																													
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																												
K	2014	Tahoe	Chassis	Suspension Control Module																																														V														
K	2014	Tahoe	Body	Body Control Module		V															V																				V																							
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																												
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Tahoe	Body	Passenger Presence Module																																																												
K	2014	Tahoe	Body	Instrument Cluster																																																												
K	2014	Tahoe	Body	Base Radio																																																												
K	2014	Tahoe	Body	Navigation Radio																																																												
K	2014	Tahoe	Body	Uplevel Radio																																																												
K	2014	Tahoe	Body	Amplifier																																																												
K	2014	Tahoe	Body	Rear Audio Control Module																																																												
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																												
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																												
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																												
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																												
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																												
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																												
K	2014	Tahoe	Body	Liftgate Control Module																																																												
K	2014	Tahoe	Body	Seat Memory Control Module																																																												
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																												
K	2014	Tahoe	Body	Assist Step Control Module																																																												
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																												
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																												
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																												
K	2014	Tahoe	Body	Parking Assist Control Module																																																												
K	2014	Tahoe	Body	Theft Deterrent Module																																																												
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2015	Suburban	Body	Radio																		V	V																																					
K	2015	Suburban	Body	Amplifier																				V	V																																			
K	2015	Suburban	Body	Media Disc Player																																																							
K	2015	Suburban	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																															
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																							
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																							
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																						
K	2015	Suburban	Body	HVAC Control Module																																																						
K	2015	Suburban	Body	Liftgate Control Module																																																						
K	2015	Suburban	Body	Keyless Entry Control Module																																																						
K	2015	Suburban	Body	Assist Step Control Module																																																						
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																						
K	2015	Suburban	Body	Parking Assist Control Module																																																						
K	2015	Suburban	Body	Frontview Camera Module																											V	V																												
K	2015	Suburban	Body	Steering Column Lock Control Module																																																						
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																						
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																						
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																						
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																						
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																					
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																					
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																											V											
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																					
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																					
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																					
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																					
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																					
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																					
K	2015	Tahoe	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																								
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																V																																							
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																					
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																					
K	2015	Tahoe	Chassis	Power Steering Control Module																			V														V																					
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																					
K	2015	Tahoe	Chassis	Suspension Control Module																																											V											
K	2015	Tahoe	Body	Body Control Module																	V																																					
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																					
K	2015	Tahoe	Body	Passenger Presence Module																																																					
K	2015	Tahoe	Body	Instrument Cluster																																																					
K	2015	Tahoe	Body	Radio Controls																																																					
K	2015	Tahoe	Body	HVAC Controls																																																					
K	2015	Tahoe	Body	Radio																		V	V																																				
K	2015	Tahoe	Body	Amplifier																				V	V																																			
K	2015	Tahoe	Body	Media Disc Player																																																					
K	2015	Tahoe	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																														
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																						
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																					
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																					
K	2015	Tahoe	Body	HVAC Control Module																																																					
K	2015	Tahoe	Body	Liftgate Control Module																																																					
K	2015	Tahoe	Body	Keyless Entry Control Module																																																					

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module																																																												
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																																												
L	2011	Captiva Sport	Body	Body Control Module																																																												
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																												
L	2011	Captiva Sport	Body	HVAC Control Module																																																												
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																																												
L	2011	Captiva Sport	Body	Passenger Presence System																																																												
L	2011	Captiva Sport	Body	Radio																																																												
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2011	Captiva Sport	Body	Rollover Sensor																																																												
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																																																												
L	2011	Captiva Sport	Body	Theft Deterrent Module																																																												
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																																												
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																												
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module							V																																																					
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																												
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2011	Equinox	Chassis	Electronic Brake Control Module											V	V	V	V	V																																													
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2011	Equinox	Body	Body Control Module																																																												
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2011	Equinox	Body	Passenger Presence Module																																																												
L	2011	Equinox	Body	Instrument Cluster																																																												
L	2011	Equinox	Body	Radio																																																												
L	2011	Equinox	Body	Multimedia Player Interface Module																																																												
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2011	Equinox	Body	Liftgate Control Module																																																												
L	2011	Equinox	Body	Parking Assist Control Module																																																												
L	2011	Equinox	Body	Frontview Camera Module																											V	V																																
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																											V																																	
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																												
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																												
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																												
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																												
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																												
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
L	2012	Equinox	Body	Multimedia Player Interface Module																																																														
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																													
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																													
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2012	Equinox	Body	Liftgate Control Module																																																												
L	2012	Equinox	Body	Parking Assist Control Module																																																												
L	2012	Equinox	Body	Frontview Camera Module																											V	V																																
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																											V																																
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																												
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																												
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																												
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																												
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																												
L	2013	Captiva	Chassis	Parking Brake Control Module																																																												
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto		V														V																						V																				
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual		V														V																						V																				
L	2013	Captiva	Body	Auxiliary Body Control Module																																																												
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2013	Captiva	Body	Instrument Cluster																																																												
L	2013	Captiva	Body	Headlamp Control Module																															V																													
L	2013	Captiva	Body	HVAC Control Module																																																												
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																												
L	2013	Captiva	Body	Theft Deterrent Module																																																												
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module								V																																																			
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																												
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																												
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module								V																																																			
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																												
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																												
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																																												
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																												
L	2013	Captiva Sport	Body	Body Control Module																																																												
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																												
L	2013	Captiva Sport	Body	Heated Seat Module																																																												
L	2013	Captiva Sport	Body	HVAC Control Module																																																												
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
L	2013	Captiva Sport	Body	Park Assist Module																																																												
L	2013	Captiva Sport	Body	Passenger Presence System																																																												
L	2013	Captiva Sport	Body	Radio																																																												
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																																												
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																												
L	2013	Captiva Sport	Body	Theft Deterrent Module																																																												
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module							V																																																					
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2013	Equinox	Chassis	Electronic Brake Control Module											V	V	V	V	V																																													
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2013	Equinox	Chassis	Power Steering Control Module																																																												
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																												
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2013	Equinox	Body	Passenger Presence Module																																																												
L	2013	Equinox	Body	Instrument Cluster																																																												
L	2013	Equinox	Body	Radio																																																												
L	2013	Equinox	Body	Rear Audio Control Module																																																												
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2013	Equinox	Body	Liftgate Control Module																																																												
L	2013	Equinox	Body	Front Seat Heating Control Module																																																												
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																												
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																												
L	2013	Equinox	Body	Parking Assist Control Module																																																												
L	2013	Equinox	Body	Frontview Camera Module																											V	V																																
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																													V																															
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module							V																																																					
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																												
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																												
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																												
L	2014	Captiva (3GN)	Body	Body Control Module		V															V																				V																							
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																												
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																												
L	2014	Captiva (3GN)	Body	Radio																																																												
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																												
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																												
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																														
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																													
L	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																													
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																													
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																													
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																													
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																													
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																													
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																													
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																													
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																													
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																													
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																													
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																													
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																													
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																													
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																													
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																													
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																													
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto		V															V																					V																							
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual		V															V																					V																							
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																													
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
L	2014	Captiva (Other)	Body	Instrument Cluster																																																													
L	2014	Captiva (Other)	Body	Headlamp Control Module																															V																														
L	2014	Captiva (Other)	Body	HVAC Control Module																																																													
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																													
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																													
L	2014	Captiva (Other)	Body	Theft Deterrent Module																																																													
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																													
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module							V																																																					
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																													
L	2014	Equinox	Chassis	Electronic Brake Control Module										V	V	V	V	V																																															
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																													
L	2014	Equinox	Chassis	Power Steering Control Module																																																													
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																													
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																													
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																													
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
L	2014	Equinox	Body	Passenger Presence Module																																																													
L	2014	Equinox	Body	Instrument Cluster																																																													
L	2014	Equinox	Body	Radio																																																													
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																													
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																													
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																													
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																													

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
R	2010	ALL	Body	Rear HVAC/RSA																																																											
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2010	ALL	Body	Theft Deterrent Module																																																											
R	2011	ALL	Powertrain	Engine Control Module																																																											
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2011	ALL	Powertrain	Transmission Control Module																																																											
R	2011	ALL	Chassis	Electronic Brake Control Module																																																											
R	2011	ALL	Body	Body Control Module																																																											
R	2011	ALL	Body	Digital Radio Receiver																																																											
R	2011	ALL	Body	Driver Door Switch																																																											
R	2011	ALL	Body	Heated Seat Module																																																											
R	2011	ALL	Body	HVAC Control Module Auto																																																											
R	2011	ALL	Body	HVAC Control Module Manual																																																											
R	2011	ALL	Body	Instrument Panel Cluster																																																											
R	2011	ALL	Body	Lift Gate Module																																																											
R	2011	ALL	Body	Park Assist Module																																																											
R	2011	ALL	Body	Passenger Door Switch																																																											
R	2011	ALL	Body	Passenger Presence System																																																											
R	2011	ALL	Body	Radio																																																											
R	2011	ALL	Body	Rear HVAC/RSA																																																											
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2011	ALL	Body	Theft Deterrent Module																																																											
R	2012	ALL	Powertrain	Engine Control Module								V																																																			
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2012	ALL	Powertrain	Transmission Control Module																																																											
R	2012	ALL	Chassis	Electronic Brake Control Module																																																											
R	2012	ALL	Body	Body Control Module																																																											
R	2012	ALL	Body	Digital Radio Receiver																																																											
R	2012	ALL	Body	Driver Door Switch																																																											
R	2012	ALL	Body	Heated Seat Module																																																											
R	2012	ALL	Body	HVAC Control Module Auto																																																											
R	2012	ALL	Body	HVAC Control Module Manual																																																											
R	2012	ALL	Body	Instrument Panel Cluster																																																											
R	2012	ALL	Body	Lift Gate Module																																																											
R	2012	ALL	Body	Park Assist Module																																																											
R	2012	ALL	Body	Passenger Door Switch																																																											
R	2012	ALL	Body	Passenger Presence System																																																											
R	2012	ALL	Body	Radio																																																											
R	2012	ALL	Body	Rear HVAC/RSA																																																											
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2012	ALL	Body	Theft Deterrent Module																																																											
R	2013	ALL	Powertrain	Engine Control Module								V																																																			
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2013	ALL	Powertrain	Transmission Control Module																																																											
R	2013	ALL	Chassis	Electronic Brake Control Module																																																											
R	2013	ALL	Body	Body Control Module																																																											
R	2013	ALL	Body	Digital Radio Receiver																																																											
R	2013	ALL	Body	Driver Door Switch																																																											
R	2013	ALL	Body	Heated Seat Module																																																											
R	2013	ALL	Body	HVAC Control Module Auto																																																											
R	2013	ALL	Body	HVAC Control Module Manual																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																												
R	2015	Traverse	Body	Liftgate Control Module																																																												
R	2015	Traverse	Body	Seat Memory Control Module																																																												
R	2015	Traverse	Body	Front Seat Heating Control Module																																																												
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																												
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																												
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																												
R	2015	Traverse	Body	Parking Assist Control Module																																																												
R	2015	Traverse	Body	Frontview Camera Module																											V	V																																
R	2015	Traverse	Body	Theft Deterrent Module																																																												
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
R	2016	Traverse	Chassis	Electronic Brake Control Module											V	V	V	V	V																																													
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate		V															V																						V																				
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)		V															V																						V																				
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2016	Traverse	Body	Passenger Presence Module																																																												
R	2016	Traverse	Body	Instrument Cluster																																																												
R	2016	Traverse	Body	Radio																																																											
R	2016	Traverse	Body	Rear Audio Control Module																																																											
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																											
R	2016	Traverse	Body	Personal Audio Link Control Module																																																											
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																											
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																											
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																											
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																											
R	2016	Traverse	Body	Liftgate Control Module																																																											
R	2016	Traverse	Body	Seat Memory Control Module																																																											
R	2016	Traverse	Body	Front Seat Heating Control Module																																																											
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																											
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																											
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																											
R	2016	Traverse	Body	Parking Assist Control Module																																																											
R	2016	Traverse	Body	Frontview Camera Module																											V	V																																
R	2016	Traverse	Body	Theft Deterrent Module																																																												
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
S	2004	S10	Chassis	4WAL 3 Sensor																																																												
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																												
S	2004	S10	Body	Body Control Module																																																											
S	2004	S10	Body	Instrument Panel Cluster																																																												
S	2004	S10	Body	Base Radio																																																											
S	2004	S10	Body	Uplevel Radio																																																											
S	2004	S10	Body	Supplemental Inflatable Restraint																																																											
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
S	2013	Trailblazer	Body	Parking Assist Control Module																																																											
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																											
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																											
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																											
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																											
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2014	Colorado	Body	Body Control Module																	V																																										
S	2014	Colorado	Body	Body Control Module																																																											
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2014	Colorado	Body	Instrument Cluster																																																											
S	2014	Colorado	Body	Radio																																																											
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																											
S	2014	Colorado	Body	Parking Assist Control Module																																																											
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																											
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																											
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																											
S	2014	S10	Powertrain	Transfer Case Control Module																																																											
S	2014	S10	Chassis	Electronic Brake Control Module																																																											
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2014	S10	Body	Body Control Module																	V																																										
S	2014	S10	Body	Body Control Module																																																											
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2014	S10	Body	Instrument Cluster																																																											
S	2014	S10	Body	Trailer Interface Control Module																																																											
S	2014	S10	Body	Radio																																																											
S	2014	S10	Body	Parking Assist Control Module																																				V	V	V																					
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																											
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																											
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																														
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module											V	V	V	V	V																																															
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																															
S	2016	Colorado (1GC)	Body	Body Control Module									V																																																					
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																																															
S	2016	Colorado (1GC)	Body	Radio Controls																																																															
S	2016	Colorado (1GC)	Body	HVAC Controls																																																															
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																															
S	2016	Colorado (1GC)	Body	Radio																		V	V																																											
S	2016	Colorado (1GC)	Body	Amplifier																				V	V																																									
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																				
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																															
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																															
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																															
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																															
S	2016	Colorado (1GC)	Body	Frontview Camera Module																											V	V																																			
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																															
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																															
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																															
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																															
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																															
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																															
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																															
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																															
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																															
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																															
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																															
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																															
S	2016	Colorado (MMM)	Body	Body Control Module									V								V																																													
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
S	2016	Colorado (MMM)	Body	Instrument Cluster																																																															
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																															
S	2016	Colorado (MMM)	Body	Radio																																																															
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																															
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																															
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																															
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																															
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																															
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																															
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																V																																
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																															
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																															
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																															
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																															
S	2016	S10	Powertrain	Transfer Case Control Module																																																															
S	2016	S10	Chassis	Electronic Brake Control Module																																																															
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																															
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																															
S	2016	S10	Body	Body Control Module									V								V																																													

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																												
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2014	Colorado	Body	Body Control Module																	V																																											
T	2014	Colorado	Body	Body Control Module																																																												
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2014	Colorado	Body	Instrument Cluster																																																												
T	2014	Colorado	Body	Radio																																																												
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																												
T	2014	Colorado	Body	Parking Assist Control Module																																																												
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																												
T	2014	S10	Powertrain	Transfer Case Control Module																																																												
T	2014	S10	Chassis	Electronic Brake Control Module																																																												
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2014	S10	Body	Body Control Module																	V																																											
T	2014	S10	Body	Body Control Module																																																												
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2014	S10	Body	Instrument Cluster																																																												
T	2014	S10	Body	Trailer Interface Control Module																																																												
T	2014	S10	Body	Radio																																																												
T	2014	S10	Body	Parking Assist Control Module																																						V	V	V																				
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																												
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																												
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																												
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																												
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2014	Trailblazer	Body	Body Control Module																	V																																											
T	2014	Trailblazer	Body	Body Control Module																																																												
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2014	Trailblazer	Body	Instrument Cluster																																																												
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																												
T	2014	Trailblazer	Body	Parking Assist Control Module																																																												
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																												
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																												
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																												
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	Colorado (1GC)	Body	Frontview Camera Module																											V	V																																
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																												
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																												
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2016	Colorado (MMM)	Body	Body Control Module									V								V																																											
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																												
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																												
T	2016	Colorado (MMM)	Body	Radio																																																												
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																												
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																												
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																											
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																												
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																V																													
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
T	2016	S10	Powertrain	Transfer Case Control Module																																																												
T	2016	S10	Chassis	Electronic Brake Control Module																																																												
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2016	S10	Body	Body Control Module									V								V																																											
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	S10	Body	Instrument Cluster																																																												
T	2016	S10	Body	Trailer Interface Control Module																																																												
T	2016	S10	Body	Radio																																																											
T	2016	S10	Body	Telematics Communication Interface Control Module																																																												
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																												
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	S10	Body	Parking Assist Control Module																																																											
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)		V															V																				V																						
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Traverse	Body	Passenger Presence Module																																																										
V	2015	Traverse	Body	Instrument Cluster																																																									
V	2015	Traverse	Body	Radio																																																									
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																									
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																									
V	2015	Traverse	Body	Liftgate Control Module																																																									
V	2015	Traverse	Body	Seat Memory Control Module																																																									
V	2015	Traverse	Body	Front Seat Heating Control Module																																																									
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																									
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																									
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																									
V	2015	Traverse	Body	Parking Assist Control Module																																																									
V	2015	Traverse	Body	Frontview Camera Module																											V	V																													
V	2015	Traverse	Body	Theft Deterrent Module																																																									
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																									
V	2016	Traverse	Chassis	Electronic Brake Control Module											V	V	V	V	V																																									
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate		V															V																				V																			
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)		V															V																				V																			
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2016	Traverse	Body	Passenger Presence Module																																																									
V	2016	Traverse	Body	Instrument Cluster																																																									
V	2016	Traverse	Body	Radio																																																									
V	2016	Traverse	Body	Rear Audio Control Module																																																									
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																									
V	2016	Traverse	Body	Personal Audio Link Control Module																																																									
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																									
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																									
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																									
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																									
V	2016	Traverse	Body	Liftgate Control Module																																																									
V	2016	Traverse	Body	Seat Memory Control Module																																																									
V	2016	Traverse	Body	Front Seat Heating Control Module																																																									
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																									
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																									
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																									
V	2016	Traverse	Body	Parking Assist Control Module																																																									
V	2016	Traverse	Body	Frontview Camera Module																											V	V																													
V	2016	Traverse	Body	Theft Deterrent Module																																																									
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																									
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																													
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																												
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																												
A	2015	Orlando	Body	Front Seat Heating Control Module																																																												
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																												
A	2015	Orlando	Body	Keyless Entry Control Module																																																												
A	2015	Orlando	Body	Parking Assist Control Module																																								V																			
A	2015	Orlando	Body	Frontview Camera Module																											V																																	
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																												
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																												
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																												
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																												
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																												
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																V																													
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																													V																															
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																													V																															
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																												
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																												
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2016	Orlando	Chassis	Power Steering Control Module																																V																											
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2016	Orlando	Body	Body Control Module									V																																																		
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2016	Orlando	Body	Instrument Cluster																																																												
A	2016	Orlando	Body	Radio																																																											
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																												
A	2016	Orlando	Body	Multimedia Player Interface Module																																																												
A	2016	Orlando	Body	Mobile Telephone Control Module																																																												
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																												
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																												
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																												
A	2016	Orlando	Body	Front Seat Heating Control Module																																																												
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																												
A	2016	Orlando	Body	Keyless Entry Control Module																																																												
A	2016	Orlando	Body	Parking Assist Control Module																																																												
A	2016	Orlando	Body	Frontview Camera Module																											V	V																															
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module								V																																																			
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module								V																																																			
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module								V																																																			
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module								V																																																			

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																													
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																													
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																													
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module								V																																																				
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																													
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																													
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																													
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																													
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																													
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																													
P	2013	Orlando	Chassis	Parking Brake Control Module																																																													
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																													
P	2013	Orlando	Chassis	Power Steering Control Module																																																													
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																													
P	2013	Orlando	Body	Body Control Module																																																													
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
P	2013	Orlando	Body	Instrument Cluster																																																													
P	2013	Orlando	Body	Radio																																																												
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																													
P	2013	Orlando	Body	Multimedia Player Interface Module																																																													
P	2013	Orlando	Body	Mobile Telephone Control Module																																																													
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																													
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																													
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																													
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																													
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																													
P	2013	Orlando	Body	Front Seat Heating Control Module																																																													
P	2013	Orlando	Body	Keyless Entry Control Module																																																													
P	2013	Orlando	Body	Parking Assist Control Module																																								V	V	V																	
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																													
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																													
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																													
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																													
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																													
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																													
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																													
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																													
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																													
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																													
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																													
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																													
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																													
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																													
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																													
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																													

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
P	2014	Orlando	Chassis	Power Steering Control Module																																																													
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2014	Orlando	Body	Body Control Module																																																												
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2014	Orlando	Body	Instrument Cluster																																																												
P	2014	Orlando	Body	Radio																																																												
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																												
P	2014	Orlando	Body	Multimedia Player Interface Module																																																												
P	2014	Orlando	Body	Mobile Telephone Control Module																																																												
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																												
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																												
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																												
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																												
P	2014	Orlando	Body	Front Seat Heating Control Module																																																												
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																												
P	2014	Orlando	Body	Keyless Entry Control Module																																																												
P	2014	Orlando	Body	Parking Assist Control Module																																								V	V	V																
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																												
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																												
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																												
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																												
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																												
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2015	Orlando	Chassis	Power Steering Control Module																																																												
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2015	Orlando	Body	Body Control Module																																																												
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2015	Orlando	Body	Instrument Cluster																																																												
P	2015	Orlando	Body	Radio																																																												
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																												
P	2015	Orlando	Body	Mobile Telephone Control Module																																																												
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																												
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																												
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																												
P	2015	Orlando	Body	Front Seat Heating Control Module																																																												
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																												
P	2015	Orlando	Body	Keyless Entry Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																													V	V																										
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																								
A	2006	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2006	ALL	Chassis	Electronic Brake Control Module																																																								
A	2006	ALL	Chassis	Power Steering Control Module																																																								
A	2006	ALL	Body	Body Control Module																																									V														
A	2006	ALL	Body	Digital Radio Receiver																																																								
A	2006	ALL	Body	Instrument Panel Cluster																																																								
A	2006	ALL	Body	Radio																																																								
A	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
A	2006	ALL	Body	Theft Deterrent Module																																																								
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																											V	V	V	V																											
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																											V	V	V	V																											
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2007	ALL	Chassis	Electronic Brake Control Module																																																								
A	2007	ALL	Chassis	Power Steering Control Module																																																								
A	2007	ALL	Body	Body Control Module																																									V														
A	2007	ALL	Body	Digital Radio Receiver																																																								
A	2007	ALL	Body	Instrument Panel Cluster																																																								
A	2007	ALL	Body	Radio																																																								
A	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
A	2007	ALL	Body	Theft Deterrent Module																																																								
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																											V	V	V	V																											
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module																											V	V	V	V																											
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module																											V	V	V	V																											
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES																																			V																				
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES																																																								
A	2008	HHR	Chassis	Power Steering Control Module																																																								
A	2008	HHR	Chassis	Power Steering Control Module																																																								
A	2008	HHR	Body	Body Control Module																																									V														
A	2008	HHR	Body	Digital Radio Receiver																																																								
A	2008	HHR	Body	Instrument Panel Cluster																																																								
A	2008	HHR	Body	Radio																																																								
A	2008	HHR	Body	Supplemental Inflatable Restraint																																					V																			V
A	2008	HHR	Body	Theft Deterrent Module																																																								
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																											V	V	V	V																											
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module																											V	V	V	V																											
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module																											V	V	V	V																											
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																			V																				
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																								
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																								
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																								
A	2008	HHR Panel	Body	Body Control Module																																									V														
A	2008	HHR Panel	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																								
A	2008	HHR Panel	Body	Radio																																																								
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																				V																				V
A	2008	HHR Panel	Body	Theft Deterrent Module																																																							
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																																							
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																																							
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																											V	V	V	V																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																											V		V	V																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																											V		V	V																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																			V																				
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																																							
A	2009	HHR	Chassis	Power Steering Control Module																																																							
A	2009	HHR	Chassis	Power Steering Control Module																																																							
A	2009	HHR	Body	Body Control Module																																									V														
A	2009	HHR	Body	Digital Radio Receiver																																																							
A	2009	HHR	Body	Instrument Panel Cluster																																																							
A	2009	HHR	Body	Radio																																																							
A	2009	HHR	Body	Supplemental Inflatable Restraint																																				V																				V
A	2009	HHR	Body	Theft Deterrent Module																																																							
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																											V	V	V	V																										
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																											V		V	V																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																											V		V	V																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																			V																				
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																							
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																							
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																							
A	2009	HHR Panel	Body	Body Control Module																																									V														
A	2009	HHR Panel	Body	Digital Radio Receiver																																																							
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																							
A	2009	HHR Panel	Body	Radio																																																							
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																				V																				V
A	2009	HHR Panel	Body	Theft Deterrent Module																																																							
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																											V	V	V	V																										
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																											V		V	V																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																											V		V	V																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																V	V	V		V	V	V	V										V																							
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																			V																				
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																																						
A	2010	HHR	Chassis	Power Steering Control Module																																																						
A	2010	HHR	Chassis	Power Steering Control Module																																																						
A	2010	HHR	Body	Body Control Module																																									V														
A	2010	HHR	Body	Digital Radio Receiver																																																							
A	2010	HHR	Body	Instrument Panel Cluster																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2010	HHR	Body	Radio																																																								
A	2010	HHR	Body	Supplemental Inflatable Restraint																																					V																			V
A	2010	HHR	Body	Theft Deterrent Module																																																								
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																											V	V	V	V																										
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																											V		V	V																										
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																											V		V	V																										
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																			V																					
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																								
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																								
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																								
A	2010	HHR Panel	Body	Body Control Module																																										V														
A	2010	HHR Panel	Body	Digital Radio Receiver																																																								
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																								
A	2010	HHR Panel	Body	Radio																																																								
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																					V																			V
A	2010	HHR Panel	Body	Theft Deterrent Module																																																								
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module																											V		V	V																										
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module																											V		V	V																										
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																			V																					
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																																								
A	2011	HHR	Chassis	Power Steering Control Module																																																								
A	2011	HHR	Body	Body Control Module																																										V														
A	2011	HHR	Body	Digital Radio Receiver																																																								
A	2011	HHR	Body	Instrument Panel Cluster																																																								
A	2011	HHR	Body	Radio																																																								
A	2011	HHR	Body	Supplemental Inflatable Restraint																																					V																			V
A	2011	HHR	Body	Theft Deterrent Module																																																								
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module																											V		V	V																										
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module																											V		V	V																										
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																V	V	V		V	V	V	V									V																								
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																			V																					
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																								
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																								
A	2011	HHR Panel	Body	Body Control Module																																										V														
A	2011	HHR Panel	Body	Digital Radio Receiver																																																								
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																								
A	2011	HHR Panel	Body	Radio																																																								
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																					V																			V
A	2011	HHR Panel	Body	Theft Deterrent Module																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
A	2013	Trax	Chassis	Electronic Brake Control Module																																																										
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Trax	Chassis	Power Steering Control Module																																																										
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	Trax	Body	Body Control Module																																																									
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	Trax	Body	Passenger Presence Module																																																										
A	2013	Trax	Body	Instrument Cluster																																																										
A	2013	Trax	Body	Radio																																																										
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
A	2013	Trax	Body	Front Seat Heating Control Module																																																										
A	2013	Trax	Body	Parking Assist Control Module																																																										
A	2013	Trax	Body	Frontview Camera Module																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																									
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																									
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																									
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																									
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																									
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																									
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module						V																																																			
A	2014	Trax	Chassis	Electronic Brake Control Module																																																									
A	2014	Trax	Chassis	Power Steering Control Module																																																									
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2014	Trax	Body	Body Control Module																																																									
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2014	Trax	Body	Passenger Presence Module																																																									
A	2014	Trax	Body	Instrument Cluster																																																									
A	2014	Trax	Body	Radio																																																									
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																									
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																									
A	2014	Trax	Body	Front Seat Heating Control Module																																																									
A	2014	Trax	Body	Parking Assist Control Module																																																									
A	2014	Trax	Body	Frontview Camera Module																																																									
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																									
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																									
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																									
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																									
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																									
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																									
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																									
A	2015	Trax	Powertrain	Chassis Control Module																																																									
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module						V																																																			
A	2015	Trax	Chassis	Electronic Brake Control Module																																																									
A	2015	Trax	Chassis	Power Steering Control Module																																																									
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2015	Trax	Body	Body Control Module																																																								
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2015	Trax	Body	Passenger Presence Module																																																									
A	2015	Trax	Body	Instrument Cluster																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2015	Trax	Body	Radio																																																								
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																								
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
A	2015	Trax	Body	Seat Memory Control Module																																																								
A	2015	Trax	Body	Front Seat Heating Control Module																																																								
A	2015	Trax	Body	Right Side Object Detection Control Module																																																								
A	2015	Trax	Body	Left Side Object Detection Control Module																																																								
A	2015	Trax	Body	Parking Assist Control Module																																																								
A	2015	Trax	Body	Frontview Camera Module																																																								
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																								
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																								
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																								
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																								
A	2016	Trax	Powertrain	Chassis Control Module																																																								
A	2016	Trax	Chassis	Electronic Brake Control Module																																																								
A	2016	Trax	Chassis	Power Steering Control Module																																																								
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2016	Trax	Body	Body Control Module																																																								
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2016	Trax	Body	Passenger Presence Module																																																								
A	2016	Trax	Body	Instrument Cluster																																																								
A	2016	Trax	Body	Trailer Interface Control Module																																																								
A	2016	Trax	Body	Radio																																																								
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																								
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
A	2016	Trax	Body	Seat Memory Control Module																																																								
A	2016	Trax	Body	Front Seat Heating Control Module																																																								
A	2016	Trax	Body	Right Side Object Detection Control Module																																																								
A	2016	Trax	Body	Left Side Object Detection Control Module																																																								
A	2016	Trax	Body	Parking Assist Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2016	Trax	Body	Frontview Camera Module																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM													V	V																																													
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																V	V	V		V	V	V																																				
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																				
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																				
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																													
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																				
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																													
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																				
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																													
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																				
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																													
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																				
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module													V	V																																													
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																V	V	V		V	V	V																																				
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module													V	V																																													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																V	V	V		V	V	V																																				
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																V	V	V		V	V	V																																				
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																													
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																				
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module													V	V																																													
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																				V	V	V	V	V																																		
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																													
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																				V	V	V	V	V																																		
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module													V	V																																													
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																V	V	V		V	V	V																																				
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																				V	V	V	V	V																																		
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																											
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
C	2004	ALL	Chassis	ESC																																																										
C	2004	ALL	Chassis	Rear Wheel Steering																																																											
C	2004	ALL	Chassis	Tire Pressure Monitor																																																											
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2004	ALL	Chassis	VSES																																																										
C	2004	ALL	Body	Amplifier (Bose)																																																											
C	2004	ALL	Body	Body Control Module																																					V	V	V																				
C	2004	ALL	Body	CD Changer																																																											
C	2004	ALL	Body	Chime																																																											
C	2004	ALL	Body	Driver Door Module																																					V	V	V																				
C	2004	ALL	Body	Driver Seat Module																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2004	ALL	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2004	ALL	Body	OnStar																																																								
C	2004	ALL	Body	Passenger Door Module																																						V	V	V																	
C	2004	ALL	Body	Passenger Presence System																																																								
C	2004	ALL	Body	Radio Base																																																								
C	2004	ALL	Body	Radio Uplevel																																																								
C	2004	ALL	Body	Radio Navigation																																																								
C	2004	ALL	Body	Rear Aux. Climate Module																																						V																		
C	2004	ALL	Body	Rear HVAC																																																								
C	2004	ALL	Body	Rear Seat Audio																																						V																		
C	2004	ALL	Body	Rear Seat Entertainment																																																								
C	2004	ALL	Body	Supplemental Inflatable Restraint																																						V	V																	
C	2004	ALL	Body	Vehicle Theft Deterrent																																						V																		
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM													V	V																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																V	V	V		V	V	V																																		
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																		
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																		
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																		
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																V	V	V		V	V	V																																		
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																		
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																		
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																V	V	V		V	V	V																																		
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																V	V	V		V	V	V																																		
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																		
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																				V	V	V	V	V																																
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																V	V	V		V	V	V																																		
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																				V	V	V	V	V																																
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																								
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																								
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																								
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
C	2005	ALL	Chassis	ESC																																																								
C	2005	ALL	Chassis	Rear Wheel Steering																																																								
C	2005	ALL	Chassis	Tire Pressure Monitor																																																								
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2005	ALL	Chassis	VSES																																																								
C	2005	ALL	Body	Amplifier (Bose)																																																								
C	2005	ALL	Body	Body Control Module																																					V	V	V																	
C	2005	ALL	Body	CD Changer																																																							
C	2005	ALL	Body	Chime																																																							
C	2005	ALL	Body	Disc Player and Video Display																																																							
C	2005	ALL	Body	Driver Door Module																																					V	V	V																	
C	2005	ALL	Body	Driver Seat Module																																																							
C	2005	ALL	Body	Generator Battery Control Module																																																							
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																							
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																							
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																							
C	2005	ALL	Body	Instrument Panel Cluster																																																							
C	2005	ALL	Body	Passenger Door Module																																					V	V	V																	
C	2005	ALL	Body	Passenger Presence System																																																							
C	2005	ALL	Body	Base Radio																																																							
C	2005	ALL	Body	Uplevel Radio																																																							
C	2005	ALL	Body	Navigation Radio																																																							
C	2005	ALL	Body	Rear Aux. Climate Module																																					V																			
C	2005	ALL	Body	Rear HVAC																																																							
C	2005	ALL	Body	Rear Seat Audio																																					V																			
C	2005	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																							
C	2005	ALL	Body	Vehicle Theft Deterrent																																					V																			
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM													V	V																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																							
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																							
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																							
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																V	V	V		V	V	V																																	
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																	
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																	
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																									
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																	
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																									
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																	
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module													V	V																																									
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																V	V	V		V	V	V																																	
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																									
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																	
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																	
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module													V	V																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module													V	V																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																V	V	V		V	V	V																																	
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																V	V	V		V	V	V																																	
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																									
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																	
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module													V	V																																									
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																				V	V	V	V	V																															

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																									
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																											
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																				V	V	V	V	V																																	
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module													V	V																																											
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																				V	V	V	V	V																																	
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																V	V	V		V	V	V																																			
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																									
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																					V	V	V																			
C	2006	ALL	Body	CD Changer																																																									
C	2006	ALL	Body	Chime																																																									
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																					V	V	V																			
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																					V	V	V																			
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																					V																					
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																					V																					
C	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																					V
C	2006	ALL	Body	Vehicle Theft Deterrent																																					V																					
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																												
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																									
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																									
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																												
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																									
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																												
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																									
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																								
C	2007	Avalanche	Body	Amplifier (Bose)																																																								
C	2007	Avalanche	Body	Assist Step Controller																																																								
C	2007	Avalanche	Body	Body Control Module			V																																			V	V																	
C	2007	Avalanche	Body	Body Control Module (aux.)																																																								
C	2007	Avalanche	Body	Digital Radio Receiver																																																								
C	2007	Avalanche	Body	Driver Door Switch																																					V	V	V																	
C	2007	Avalanche	Body	HVAC Control Module Auto																																						V		V																
C	2007	Avalanche	Body	HVAC Control Module Manual																																						V		V																
C	2007	Avalanche	Body	Instrument Panel Cluster																																																								
C	2007	Avalanche	Body	Memory Seat Module																																																								
C	2007	Avalanche	Body	Park Assist Module																																																								
C	2007	Avalanche	Body	Passenger Door Switch																																					V	V	V																	
C	2007	Avalanche	Body	Passenger Presence System																																					V																			
C	2007	Avalanche	Body	Radio																																																								
C	2007	Avalanche	Body	Rear Heated Seat Module																																																								
C	2007	Avalanche	Body	Rear HVAC/RSA																																																								
C	2007	Avalanche	Body	Rollover Sensor																																																								
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																					V																			
C	2007	Avalanche	Body	Theft Deterrent Module																																																								
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module															V	V	V		V													V																								
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module															V	V	V		V													V																								
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module															V	V	V		V													V																								
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																										
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module															V	V	V		V	V	V																																			
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																										
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module															V	V	V		V													V																								
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2007	Suburban	Chassis	Electronic Suspension Control																																																								
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																								
C	2007	Suburban	Body	Amplifier (Bose)																																																								
C	2007	Suburban	Body	Assist Step Controller																																																								
C	2007	Suburban	Body	Body Control Module			V																																			V	V																	
C	2007	Suburban	Body	Body Control Module (aux.)																																																								
C	2007	Suburban	Body	Digital Radio Receiver																																																								
C	2007	Suburban	Body	Driver Door Switch																																					V	V	V																	
C	2007	Suburban	Body	HVAC Control Module Auto																																						V		V																
C	2007	Suburban	Body	HVAC Control Module Manual																																						V		V																
C	2007	Suburban	Body	Instrument Panel Cluster																																																								
C	2007	Suburban	Body	Lift Gate Module																																					V																		
C	2007	Suburban	Body	Memory Seat Module																																																								
C	2007	Suburban	Body	Park Assist Module																																																								
C	2007	Suburban	Body	Passenger Door Switch																																					V	V	V																	
C	2007	Suburban	Body	Passenger Presence System																																					V																		
C	2007	Suburban	Body	Radio																																																								
C	2007	Suburban	Body	Rear Heated Seat Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2007	Suburban	Body	Rear HVAC/RSA																																																									
C	2007	Suburban	Body	Rollover Sensor																																																									
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																					V																					
C	2007	Suburban	Body	Theft Deterrent Module																																																									
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																												
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V													V																									
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																												
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																									
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																												
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																									
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																												
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																									
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																									
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																												
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																									
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																												
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																								
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																												
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																									
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																												
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																	
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2007	Silverado	Chassis	Electronic Suspension Control																																																									
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																									
C	2007	Silverado	Body	Amplifier (Bose)																																																									
C	2007	Silverado	Body	Body Control Module			V																																			V	V																		
C	2007	Silverado	Body	Body Control Module (aux.)																																																									
C	2007	Silverado	Body	Digital Radio Receiver																																																									
C	2007	Silverado	Body	Driver Door Switch																																					V	V	V																		
C	2007	Silverado	Body	HVAC Control Module Auto																																						V		V																	
C	2007	Silverado	Body	HVAC Control Module Manual																																						V		V																	
C	2007	Silverado	Body	Instrument Panel Cluster																																																									
C	2007	Silverado	Body	Memory Seat Module																																																									
C	2007	Silverado	Body	Park Assist Module																																																									
C	2007	Silverado	Body	Passenger Door Switch																																					V	V	V																		
C	2007	Silverado	Body	Passenger Presence System																																					V																				
C	2007	Silverado	Body	Radio																																																									
C	2007	Silverado	Body	Rear Heated Seat Module																																																									
C	2007	Silverado	Body	Rear HVAC/RSA																																																									
C	2007	Silverado	Body	Rollover Sensor																																																									
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																					V																				
C	2007	Silverado	Body	Theft Deterrent Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																										
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																							
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																							
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																							
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																							
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																						
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																						
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																						
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																						
C	2007	Tahoe	Body	Amplifier (Bose)																																																						
C	2007	Tahoe	Body	Assist Step Controller																																																						
C	2007	Tahoe	Body	Body Control Module			V																																			V	V																
C	2007	Tahoe	Body	Body Control Module (aux.)																																																						
C	2007	Tahoe	Body	Digital Radio Receiver																																																						
C	2007	Tahoe	Body	Driver Door Switch																																					V	V	V																
C	2007	Tahoe	Body	HVAC Control Module Auto																																						V		V															
C	2007	Tahoe	Body	HVAC Control Module Manual																																						V		V															
C	2007	Tahoe	Body	Instrument Panel Cluster																																																						
C	2007	Tahoe	Body	Lift Gate Module																																					V																	
C	2007	Tahoe	Body	Memory Seat Module																																																						
C	2007	Tahoe	Body	Park Assist Module																																																						
C	2007	Tahoe	Body	Passenger Door Switch																																					V	V	V																
C	2007	Tahoe	Body	Passenger Presence System																																					V																	
C	2007	Tahoe	Body	Radio																																																						
C	2007	Tahoe	Body	Rear Heated Seat Module																																																						
C	2007	Tahoe	Body	Rear HVAC/RSA																																																						
C	2007	Tahoe	Body	Rollover Sensor																																																						
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																					V																	
C	2007	Tahoe	Body	Theft Deterrent Module																																																						
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																							
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																						
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																							
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																						
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																							
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																						
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																							
C	2008	Avalanche	Chassis	Electronic Brake Control Module																																			V																				
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																						
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																						
C	2008	Avalanche	Body	Amplifier (Bose)																																																						
C	2008	Avalanche	Body	Assist Step Controller																																																						
C	2008	Avalanche	Body	Body Control Module			V																																			V	V																
C	2008	Avalanche	Body	Body Control Module (aux.)																																																						
C	2008	Avalanche	Body	Digital Radio Receiver																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2008	Avalanche	Body	Driver Door Switch																																					V	V	V																
C	2008	Avalanche	Body	HVAC Control Module Auto																																						V		V															
C	2008	Avalanche	Body	HVAC Control Module Manual																																						V		V															
C	2008	Avalanche	Body	Instrument Panel Cluster																																																						
C	2008	Avalanche	Body	Memory Seat Module																																																						
C	2008	Avalanche	Body	Park Assist Module																																																						
C	2008	Avalanche	Body	Passenger Door Switch																																					V	V	V																
C	2008	Avalanche	Body	Passenger Presence System																																					V																		
C	2008	Avalanche	Body	Radio																																																						
C	2008	Avalanche	Body	Rear Heated Seat Module																																																						
C	2008	Avalanche	Body	Rear HVAC/RSA																																																						
C	2008	Avalanche	Body	Rollover Sensor																																																						
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																					V																		
C	2008	Avalanche	Body	Theft Deterrent Module																																																						
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																									
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																							
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																									
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																						
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																							
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																									
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																						
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																							
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																									
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																					
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																									
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																						
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																							
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																				V																		
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																						
C	2008	Suburban	Chassis	Electronic Suspension Control																																																						
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																						
C	2008	Suburban	Body	Amplifier (Bose)																																																						
C	2008	Suburban	Body	Assist Step Controller																																																						
C	2008	Suburban	Body	Body Control Module			V																																			V	V																
C	2008	Suburban	Body	Body Control Module (aux.)																																																						
C	2008	Suburban	Body	Digital Radio Receiver																																																						
C	2008	Suburban	Body	Driver Door Switch																																					V	V	V																
C	2008	Suburban	Body	HVAC Control Module Auto																																						V		V															
C	2008	Suburban	Body	HVAC Control Module Manual																																						V		V															
C	2008	Suburban	Body	Instrument Panel Cluster																																																						
C	2008	Suburban	Body	Lift Gate Module																																					V																		
C	2008	Suburban	Body	Memory Seat Module																																																						
C	2008	Suburban	Body	Park Assist Module																																																						
C	2008	Suburban	Body	Passenger Door Switch																																					V	V	V																
C	2008	Suburban	Body	Passenger Presence System																																					V																		
C	2008	Suburban	Body	Radio																																																						
C	2008	Suburban	Body	Rear Heated Seat Module																																																						
C	2008	Suburban	Body	Rear HVAC/RSA																																																						
C	2008	Suburban	Body	Rollover Sensor																																																						
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																					V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2008	Suburban	Body	Theft Deterrent Module																																																								
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																										V		V																												
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V													V																								
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																										V		V	V																											
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																								
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																										V		V	V																											
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																								
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																										V		V	V																											
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																								
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																										V		V	V																											
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																								
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																										V		V	V																											
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																								
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																										V		V	V																											
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																							
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																										V		V	V																											
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																								
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																										V			V																											
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																							
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																							
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																			V																					
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																							
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																							
C	2008	Silverado	Chassis	Electronic Suspension Control																																																							
C	2008	Silverado	Chassis	Trailer Brake Control Module																																																							
C	2008	Silverado	Body	Amplifier (Bose)																																																							
C	2008	Silverado	Body	Body Control Module			V																																			V	V																
C	2008	Silverado	Body	Body Control Module (aux.)																																																							
C	2008	Silverado	Body	Digital Radio Receiver																																																							
C	2008	Silverado	Body	Driver Door Switch																																					V	V	V																
C	2008	Silverado	Body	HVAC Control Module Auto																																						V		V															
C	2008	Silverado	Body	HVAC Control Module Manual																																						V		V															
C	2008	Silverado	Body	Instrument Panel Cluster																																																							
C	2008	Silverado	Body	Memory Seat Module																																																							
C	2008	Silverado	Body	Park Assist Module																																																							
C	2008	Silverado	Body	Passenger Door Switch																																					V	V	V																
C	2008	Silverado	Body	Passenger Presence System																																					V																		
C	2008	Silverado	Body	Radio																																																							
C	2008	Silverado	Body	Rear Heated Seat Module																																																							
C	2008	Silverado	Body	Rear HVAC/RSA																																																							
C	2008	Silverado	Body	Rollover Sensor																																																							
C	2008	Silverado	Body	Supplemental Inflatable Restraint																																					V																		
C	2008	Silverado	Body	Theft Deterrent Module																																																							
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																																							
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																										V		V	V																											
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																							
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V												V																								
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																							
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V												V																								
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																							
C	2008	Tahoe	Chassis	Electronic Brake Control Module																																			V																					
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																							
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																							
C	2008	Tahoe	Body	Amplifier (Bose)																																																							
C	2008	Tahoe	Body	Assist Step Controller																																																							
C	2008	Tahoe	Body	Body Control Module			V																																			V	V																	
C	2008	Tahoe	Body	Body Control Module (aux.)																																																							
C	2008	Tahoe	Body	Digital Radio Receiver																																																							
C	2008	Tahoe	Body	Driver Door Switch																																					V	V	V																	
C	2008	Tahoe	Body	HVAC Control Module Auto																																						V		V																
C	2008	Tahoe	Body	HVAC Control Module Manual																																						V		V																
C	2008	Tahoe	Body	Instrument Panel Cluster																																																							
C	2008	Tahoe	Body	Memory Seat Module																																																							
C	2008	Tahoe	Body	Park Assist Module																																																							
C	2008	Tahoe	Body	Passenger Presence System																																					V																		
C	2008	Tahoe	Body	Radio																																																							
C	2008	Tahoe	Body	Rear Heated Seat Module																																																							
C	2008	Tahoe	Body	Rear HVAC/RSA																																																							
C	2008	Tahoe	Body	Rollover Sensor																																																							
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																					V																		
C	2008	Tahoe	Body	Theft Deterrent Module																																																							
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V		V																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																							
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																							
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																							
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																							
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																							
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																							
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																							
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																							
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																							
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																							
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																							
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																							
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																							
C	2008	Tahoe Hybrid	Body	Body Control Module			V																																			V	V																	
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																							
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																							
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																					V	V	V																	
C	2008	Tahoe Hybrid	Body	HVAC Control Module																																						V		V																
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																							
C	2008	Tahoe Hybrid	Body	Memory Seat Module																																																							
C	2008	Tahoe Hybrid	Body	Park Assist Module																																																							
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																					V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2008	Tahoe Hybrid	Body	Radio																																																								
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																																								
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																					V																			
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																	V	V																						
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																	V	V																						
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																	V	V																						
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																	V	V																						
C	2009	Avalanche	Chassis	Electronic Brake Control Module																																				V																				
C	2009	Avalanche	Chassis	Electronic Suspension Control																																																								
C	2009	Avalanche	Chassis	Trailer Brake Control Module																																																								
C	2009	Avalanche	Body	Amplifier (Bose)																																																								
C	2009	Avalanche	Body	Assist Step Controller																																																								
C	2009	Avalanche	Body	Body Control Module			V																																			V	V																	
C	2009	Avalanche	Body	Body Control Module (aux.)																																																								
C	2009	Avalanche	Body	Digital Radio Receiver																																																								
C	2009	Avalanche	Body	Driver Door Switch																																					V	V	V																	
C	2009	Avalanche	Body	HVAC Control Module Auto																																							V		V															
C	2009	Avalanche	Body	HVAC Control Module Manual																																							V		V															
C	2009	Avalanche	Body	Instrument Panel Cluster																																																								
C	2009	Avalanche	Body	Memory Seat Module																																																								
C	2009	Avalanche	Body	Park Assist Module																																																								
C	2009	Avalanche	Body	Passenger Door Switch																																					V	V	V																	
C	2009	Avalanche	Body	Passenger Presence System																																					V																			
C	2009	Avalanche	Body	Radio																																																								
C	2009	Avalanche	Body	Rear Heated Seat Module																																																								
C	2009	Avalanche	Body	Rear HVAC/RSA																																																								
C	2009	Avalanche	Body	Rollover Sensor																																																								
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																																					V																			
C	2009	Avalanche	Body	Theft Deterrent Module																																																								
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V	V	V											V																							
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V	V	V											V																							
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																				V																				

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																										
C	2009	Cheyenne	Body	Amplifier (Bose)																																																										
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2009	Cheyenne	Body	Digital Radio Receiver																																																										
C	2009	Cheyenne	Body	Driver Door Switch																																					V	V	V																			
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2009	Cheyenne	Body	Park Assist Module																																																										
C	2009	Cheyenne	Body	Passenger Door Switch																																					V	V	V																			
C	2009	Cheyenne	Body	Passenger Presence System																																					V																			
C	2009	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2009	Cheyenne	Body	Rollover Sensor																																																										
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																					V																			
C	2009	Cheyenne	Body	Theft Deterrent Module																																																										
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																												
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																								
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																												
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																	V	V																								
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																												
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																								
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																												
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																	V	V																								
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																												
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																								
C	2009	Suburban	Chassis	EBCM Under 8600 GVW																																				V																					
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2009	Suburban	Chassis	Electronic Suspension Control																																																										
C	2009	Suburban	Chassis	Trailer Brake Control Module																																																										
C	2009	Suburban	Body	Amplifier (Bose)																																																										
C	2009	Suburban	Body	Assist Step Controller																																																										
C	2009	Suburban	Body	Body Control Module			V																																			V	V																		
C	2009	Suburban	Body	Body Control Module (aux.)																																																										
C	2009	Suburban	Body	Digital Radio Receiver																																																										
C	2009	Suburban	Body	Driver Door Switch																																					V	V	V																			
C	2009	Suburban	Body	HVAC Control Module Auto																																						V		V																	
C	2009	Suburban	Body	HVAC Control Module Manual																																						V		V																	
C	2009	Suburban	Body	Instrument Panel Cluster																																																										
C	2009	Suburban	Body	Left Side Object Detection Module																																																										
C	2009	Suburban	Body	Lift Gate Module																																					V																			
C	2009	Suburban	Body	Memory Seat Module																																																										
C	2009	Suburban	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2009	Suburban	Body	Passenger Door Switch																																					V	V	V																
C	2009	Suburban	Body	Passenger Presence System																																					V																		
C	2009	Suburban	Body	Radio																																																							
C	2009	Suburban	Body	Rear Heated Seat Module																																																							
C	2009	Suburban	Body	Rear HVAC/RSA																																																							
C	2009	Suburban	Body	Right Side Object Detection Module																																																							
C	2009	Suburban	Body	Rollover Sensor																																																							
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																					V																		
C	2009	Suburban	Body	Theft Deterrent Module																																																							
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																											
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																										
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																							
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V											V																							
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																							
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																	V	V																						
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																	V	V																						
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																							
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																	V	V																						
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																										
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																											V		V	V																										
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																						
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																										
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																							
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																	V	V																						
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																							
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																										
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																							
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																							
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																				V																				
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																							
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																							
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																							
C	2009	Silverado	Chassis	Electronic Suspension Control																																																							
C	2009	Silverado	Chassis	Trailer Brake Control Module																																																							
C	2009	Silverado	Body	Amplifier (Bose)																																																							
C	2009	Silverado	Body	Body Control Module			V																																			V	V																	
C	2009	Silverado	Body	Body Control Module (aux.)																																																							
C	2009	Silverado	Body	Digital Radio Receiver																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2009	Silverado	Body	Driver Door Switch																																					V	V	V																
C	2009	Silverado	Body	HVAC Control Module Auto																																						V		V															
C	2009	Silverado	Body	HVAC Control Module Manual																																						V		V															
C	2009	Silverado	Body	Instrument Panel Cluster																																																						
C	2009	Silverado	Body	Memory Seat Module																																																						
C	2009	Silverado	Body	Park Assist Module																																																						
C	2009	Silverado	Body	Passenger Door Switch																																					V	V	V																
C	2009	Silverado	Body	Passenger Presence System																																					V																		
C	2009	Silverado	Body	Radio																																																						
C	2009	Silverado	Body	Rear Heated Seat Module																																																						
C	2009	Silverado	Body	Rear HVAC/RSA																																																						
C	2009	Silverado	Body	Rollover Sensor																																																						
C	2009	Silverado	Body	Supplemental Inflatable Restraint																																					V																		
C	2009	Silverado	Body	Theft Deterrent Module																																																						
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																										V			V																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																							
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																						
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																						
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																						
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																						
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																						
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																						
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																						
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																						
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																						
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																						
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																						
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																						
C	2009	Silverado Hybrid	Body	Body Control Module			V																																			V	V																
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																						
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																						
C	2009	Silverado Hybrid	Body	Driver Door Switch																																					V	V	V																
C	2009	Silverado Hybrid	Body	HVAC Control Module																																						V		V															
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																						
C	2009	Silverado Hybrid	Body	Memory Seat Module																																																						
C	2009	Silverado Hybrid	Body	Park Assist Module																																																						
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																					V	V	V																
C	2009	Silverado Hybrid	Body	Passenger Presence System																																					V																		
C	2009	Silverado Hybrid	Body	Radio																																																						
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																						
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																						
C	2009	Silverado Hybrid	Body	Rollover Sensor																																																						
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																						
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																					V																		
C	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																						
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																										V		V	V																										
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																						
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V										V																							
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																										V		V	V																										
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V	V	V											V																							
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																V	V																							
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																						
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																V	V																							
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V	V	V											V																							
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																						
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																V	V																							
C	2009	Tahoe	Chassis	Electronic Brake Control Module																																			V																					
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																							
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																																							
C	2009	Tahoe	Body	Amplifier (Bose)																																																						
C	2009	Tahoe	Body	Assist Step Controller																																																						
C	2009	Tahoe	Body	Body Control Module			V																																			V	V																
C	2009	Tahoe	Body	Body Control Module (aux.)																																																						
C	2009	Tahoe	Body	Digital Radio Receiver																																																						
C	2009	Tahoe	Body	Driver Door Switch																																					V	V	V																
C	2009	Tahoe	Body	HVAC Control Module Auto																																						V		V															
C	2009	Tahoe	Body	HVAC Control Module Manual																																						V		V															
C	2009	Tahoe	Body	Instrument Panel Cluster																																																						
C	2009	Tahoe	Body	Left Side Object Detection Module																																																						
C	2009	Tahoe	Body	Lift Gate Module																																					V																		
C	2009	Tahoe	Body	Memory Seat Module																																																						
C	2009	Tahoe	Body	Park Assist Module																																																						
C	2009	Tahoe	Body	Passenger Door Switch																																					V	V	V																
C	2009	Tahoe	Body	Passenger Presence System																																					V																		
C	2009	Tahoe	Body	Radio																																																						
C	2009	Tahoe	Body	Rear Heated Seat Module																																																						
C	2009	Tahoe	Body	Rear HVAC/RSA																																																						
C	2009	Tahoe	Body	Right Side Object Detection Module																																																						
C	2009	Tahoe	Body	Rollover Sensor																																																						
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																					V																		
C	2009	Tahoe	Body	Theft Deterrent Module																																																						
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																						
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																						
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																						
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																						
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																						
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																						
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																						
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																						
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																						
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																						
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																						
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																						
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																						
C	2009	Tahoe Hybrid	Body	Body Control Module			V																																			V	V																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																					V	V	V																			
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																																									
C	2009	Tahoe Hybrid	Body	HVAC Control Module																																						V		V																		
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2009	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																					V	V	V																		
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																					V																				
C	2009	Tahoe Hybrid	Body	Radio																																																									
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																										
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																					V																				
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																													
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																													
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																								
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Avalanche	Chassis	Electronic Brake Control Module																																			V																							
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Avalanche	Body	Amplifier (Bose)																																																										
C	2010	Avalanche	Body	Assist Step Controller																																																										
C	2010	Avalanche	Body	Body Control Module			V																																			V	V																		
C	2010	Avalanche	Body	Body Control Module (aux.)																																																										
C	2010	Avalanche	Body	Digital Radio Receiver																																																										
C	2010	Avalanche	Body	Driver Door Switch																																					V	V	V																		
C	2010	Avalanche	Body	HVAC Control Module Auto																																						V		V																		
C	2010	Avalanche	Body	HVAC Control Module Manual																																						V		V																		
C	2010	Avalanche	Body	Instrument Panel Cluster																																																										
C	2010	Avalanche	Body	Memory Seat Module																																																										
C	2010	Avalanche	Body	Park Assist Module																																																										
C	2010	Avalanche	Body	Passenger Door Switch																																					V	V	V																		
C	2010	Avalanche	Body	Passenger Presence System																																					V																				
C	2010	Avalanche	Body	Radio																																																									
C	2010	Avalanche	Body	Rear Heated Seat Module																																																										
C	2010	Avalanche	Body	Rear HVAC/RSA																																																										
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2010	Avalanche	Body	Theft Deterrent Module																																																										
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																													
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																													
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																				V																				
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																							
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																							
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																							
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																							
C	2010	Cheyenne	Body	Amplifier (Bose)																																																							
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																							
C	2010	Cheyenne	Body	Digital Radio Receiver																																																							
C	2010	Cheyenne	Body	Driver Door Switch																																					V	V	V																		
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																							
C	2010	Cheyenne	Body	Park Assist Module																																																							
C	2010	Cheyenne	Body	Passenger Door Switch																																					V	V	V																		
C	2010	Cheyenne	Body	Passenger Presence System																																					V																			
C	2010	Cheyenne	Body	Rear Heated Seat Module																																																							
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																							
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																							
C	2010	Cheyenne	Body	Theft Deterrent Module																																																							
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																														V																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																							
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
C	2010	Suburban	Chassis	EBCM Under 8600 GVW																																				V																				
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																							
C	2010	Suburban	Chassis	Electronic Suspension Control																																																							
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																							
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																							
C	2010	Suburban	Body	Amplifier (Bose)																																																							
C	2010	Suburban	Body	Assist Step Controller																																																							
C	2010	Suburban	Body	Body Control Module			V																																			V	V																	
C	2010	Suburban	Body	Body Control Module (aux.)																																																							
C	2010	Suburban	Body	Digital Radio Receiver																																																							
C	2010	Suburban	Body	Driver Door Switch																																					V	V	V																		
C	2010	Suburban	Body	HVAC Control Module Auto																																							V		V																
C	2010	Suburban	Body	HVAC Control Module Manual																																							V		V																
C	2010	Suburban	Body	Instrument Panel Cluster																																																							
C	2010	Suburban	Body	Left Side Object Detection Module																																																							
C	2010	Suburban	Body	Lift Gate Module																																					V																			
C	2010	Suburban	Body	Memory Seat Module																																																							
C	2010	Suburban	Body	Park Assist Module																																																							
C	2010	Suburban	Body	Passenger Door Switch																																					V	V	V																		
C	2010	Suburban	Body	Passenger Presence System																																					V																			
C	2010	Suburban	Body	Radio																																																							
C	2010	Suburban	Body	Rear Heated Seat Module																																																							
C	2010	Suburban	Body	Rear HVAC/RSA																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2010	Suburban	Body	Right Side Object Detection Module																																																									
C	2010	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2010	Suburban	Body	Theft Deterrent Module																																																										
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																											V		V	V																												
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																											V		V	V																												
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																									
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																												
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																									
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																												
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																								
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																												
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																								
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																											V		V	V																												
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																											V		V	V																												
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																								
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																												
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																								
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																												
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																		
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																			V																							
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2010	Silverado	Chassis	Electronic Suspension Control																																																										
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2010	Silverado	Body	Amplifier (Bose)																																																										
C	2010	Silverado	Body	Body Control Module			V																																			V	V																		
C	2010	Silverado	Body	Body Control Module (aux.)																																																										
C	2010	Silverado	Body	Digital Radio Receiver																																																										
C	2010	Silverado	Body	Driver Door Switch																																					V	V	V																		
C	2010	Silverado	Body	HVAC Control Module Auto																																						V		V																	
C	2010	Silverado	Body	HVAC Control Module Manual																																						V		V																	
C	2010	Silverado	Body	Instrument Panel Cluster																																																										
C	2010	Silverado	Body	Memory Seat Module																																																										
C	2010	Silverado	Body	Park Assist Module																																																										
C	2010	Silverado	Body	Passenger Door Switch																																					V	V	V																		
C	2010	Silverado	Body	Passenger Presence System																																					V																				
C	2010	Silverado	Body	Radio																																																										
C	2010	Silverado	Body	Rear Heated Seat Module																																																										
C	2010	Silverado	Body	Rear HVAC/RSA																																																										
C	2010	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2010	Silverado	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																										V			V																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																								
C	2010	Silverado Hybrid	Body	Body Control Module			V																																			V	V																		
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																								
C	2010	Silverado Hybrid	Body	Driver Door Switch																																					V	V	V																		
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																								
C	2010	Silverado Hybrid	Body	HVAC Control Module																																							V		V																	
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
C	2010	Silverado Hybrid	Body	Park Assist Module																																																								
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																					V	V	V																		
C	2010	Silverado Hybrid	Body	Passenger Presence System																																					V																			
C	2010	Silverado Hybrid	Body	Radio																																																								
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																								
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																										V		V	V																											
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																V	V																							
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																													V																											
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2010	Tahoe	Chassis	Electronic Brake Control Module																																			V																					
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																								
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Tahoe	Body	Amplifier (Bose)																																																								
C	2010	Tahoe	Body	Assist Step Controller																																																								
C	2010	Tahoe	Body	Body Control Module			V																																			V	V																	
C	2010	Tahoe	Body	Body Control Module (aux.)																																																								
C	2010	Tahoe	Body	Digital Radio Receiver																																																								
C	2010	Tahoe	Body	Driver Door Switch																																					V	V	V																		
C	2010	Tahoe	Body	HVAC Control Module Auto																																							V		V															
C	2010	Tahoe	Body	HVAC Control Module Manual																																							V		V															
C	2010	Tahoe	Body	Instrument Panel Cluster																																																								
C	2010	Tahoe	Body	Left Side Object Detection Module																																																								
C	2010	Tahoe	Body	Lift Gate Module																																					V																			
C	2010	Tahoe	Body	Memory Seat Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2010	Tahoe	Body	Park Assist Module																																																									
C	2010	Tahoe	Body	Passenger Door Switch																																					V	V	V																		
C	2010	Tahoe	Body	Passenger Presence System																																					V																			
C	2010	Tahoe	Body	Radio																																																								
C	2010	Tahoe	Body	Rear Heated Seat Module																																																								
C	2010	Tahoe	Body	Rear HVAC/RSA																																																								
C	2010	Tahoe	Body	Right Side Object Detection Module																																																								
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																								
C	2010	Tahoe	Body	Theft Deterrent Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
C	2010	Tahoe Hybrid	Body	Body Control Module			V																																			V	V																		
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																					V	V	V																		
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																																								
C	2010	Tahoe Hybrid	Body	HVAC Control Module																																						V		V																	
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																					V																			
C	2010	Tahoe Hybrid	Body	Park Assist Module																																																								
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																					V	V	V																		
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																					V																			
C	2010	Tahoe Hybrid	Body	Radio																																																								
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																											
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2011	Avalanche	Chassis	Electronic Brake Control Module																																			V																					
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																								
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2011	Avalanche	Body	Amplifier (Bose)																																																								
C	2011	Avalanche	Body	Assist Step Controller																																																								
C	2011	Avalanche	Body	Body Control Module			V																																			V	V																	
C	2011	Avalanche	Body	Body Control Module (aux.)																																																								
C	2011	Avalanche	Body	Digital Radio Receiver																																																								
C	2011	Avalanche	Body	Driver Door Switch																																					V	V	V																	
C	2011	Avalanche	Body	HVAC Control Module Auto																																						V		V																
C	2011	Avalanche	Body	HVAC Control Module Manual																																						V		V																
C	2011	Avalanche	Body	Instrument Panel Cluster																																																								
C	2011	Avalanche	Body	Memory Seat Module																																																								
C	2011	Avalanche	Body	Park Assist Module																																																								
C	2011	Avalanche	Body	Passenger Door Switch																																					V	V	V																	
C	2011	Avalanche	Body	Passenger Presence System																																					V																			
C	2011	Avalanche	Body	Radio																																																								
C	2011	Avalanche	Body	Rear Heated Seat Module																																																								
C	2011	Avalanche	Body	Rear HVAC/RSA																																																								
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																								
C	2011	Avalanche	Body	Theft Deterrent Module																																																								
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																								
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																								
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																								
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																								
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																								
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																								
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																								
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																								
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																								
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																								
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																								
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																								
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																								
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																								
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																								
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																								
C	2011	Captiva	Chassis	Electronic Brake Control Module																																																								
C	2011	Captiva	Chassis	Parking Brake Control Module																																																								
C	2011	Captiva	Body	Body Control Module																																																								
C	2011	Captiva	Body	Auxiliary Body Control Module																																																								
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2011	Captiva	Body	Instrument Cluster																																																								
C	2011	Captiva	Body	Headlamp Control Module																																																								
C	2011	Captiva	Body	HVAC Control Module																																																								
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																								
C	2011	Captiva	Body	Parking Assist Control Module																																																								
C	2011	Captiva	Body	Theft Deterrent Module																																																								
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																												V		V	V																										
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																												V		V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																						
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																			V																			
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																						
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																						
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																						
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																						
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																						
C	2011	Cheyenne	Body	Amplifier (Bose)																																																						
C	2011	Cheyenne	Body	Body Control Module			V																																			V	V																
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																						
C	2011	Cheyenne	Body	Digital Radio Receiver																																																						
C	2011	Cheyenne	Body	Driver Door Switch																																					V	V	V																	
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																						
C	2011	Cheyenne	Body	Park Assist Module																																																						
C	2011	Cheyenne	Body	Passenger Door Switch																																					V	V	V																	
C	2011	Cheyenne	Body	Passenger Presence System																																					V																		
C	2011	Cheyenne	Body	Rear Heated Seat Module																																																						
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																						
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																						
C	2011	Cheyenne	Body	Theft Deterrent Module																																																						
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																V	V																						
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																						
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																														V																									
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																						
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																						
C	2011	Suburban	Chassis	EBCM Under 8600 GVW																																			V																				
C	2011	Suburban	Chassis	Electronic Suspension Control																																																						
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																						
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																						
C	2011	Suburban	Body	Amplifier (Bose)																																																						
C	2011	Suburban	Body	Assist Step Controller																																																						
C	2011	Suburban	Body	Body Control Module			V																																			V	V																
C	2011	Suburban	Body	Body Control Module (aux.)																																																						
C	2011	Suburban	Body	Digital Radio Receiver																																																						
C	2011	Suburban	Body	Driver Door Switch																																					V	V	V																	
C	2011	Suburban	Body	HVAC Control Module Auto																																						V		V															
C	2011	Suburban	Body	HVAC Control Module Manual																																						V		V															
C	2011	Suburban	Body	Instrument Panel Cluster																																																						
C	2011	Suburban	Body	Left Side Object Detection Module																																																						
C	2011	Suburban	Body	Lift Gate Module																																					V																	
C	2011	Suburban	Body	Memory Seat Module																																																						
C	2011	Suburban	Body	Park Assist Module																																																						
C	2011	Suburban	Body	Passenger Door Switch																																					V	V	V																	
C	2011	Suburban	Body	Passenger Presence System																																					V																		
C	2011	Suburban	Body	Radio																																																						
C	2011	Suburban	Body	Rear Heated Seat Module																																																						
C	2011	Suburban	Body	Rear HVAC/RSA																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2011	Suburban	Body	Right Side Object Detection Module																																																									
C	2011	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2011	Suburban	Body	Theft Deterrent Module																																																										
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																											V		V	V																												
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																											V		V	V																												
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																												
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																								
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																												
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																								
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																											V		V	V																												
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																											V		V	V																												
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																								
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																												
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																								
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																											V			V																												
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																				V	V	V	V	V																																		
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																												
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																				V	V	V	V	V																																		
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																			V																							
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2011	Silverado	Chassis	Electronic Suspension Control																																																										
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2011	Silverado	Body	Amplifier (Bose)																																																										
C	2011	Silverado	Body	Body Control Module			V																																			V	V																		
C	2011	Silverado	Body	Body Control Module (aux.)																																																										
C	2011	Silverado	Body	Digital Radio Receiver																																																										
C	2011	Silverado	Body	Driver Door Switch																																					V	V	V																		
C	2011	Silverado	Body	HVAC Control Module Auto																																						V		V																	
C	2011	Silverado	Body	HVAC Control Module Manual																																						V		V																	
C	2011	Silverado	Body	Instrument Panel Cluster																																																										
C	2011	Silverado	Body	Memory Seat Module																																																										
C	2011	Silverado	Body	Park Assist Module																																																										
C	2011	Silverado	Body	Passenger Door Switch																																					V	V	V																		
C	2011	Silverado	Body	Passenger Presence System																																					V																				
C	2011	Silverado	Body	Radio																																																									
C	2011	Silverado	Body	Rear Heated Seat Module																																																										
C	2011	Silverado	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																																								
C	2011	Silverado	Body	Theft Deterrent Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																								
C	2011	Silverado Hybrid	Body	Body Control Module			V																																				V	V																
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																								
C	2011	Silverado Hybrid	Body	Driver Door Switch																																					V	V	V																	
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																								
C	2011	Silverado Hybrid	Body	HVAC Control Module																																						V		V																
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
C	2011	Silverado Hybrid	Body	Park Assist Module																																																								
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																					V	V	V																	
C	2011	Silverado Hybrid	Body	Passenger Presence System																																					V																			
C	2011	Silverado Hybrid	Body	Radio																																																								
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																								
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																														V																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2011	Tahoe	Chassis	Electronic Brake Control Module																																			V																					
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																								
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Tahoe	Body	Amplifier (Bose)																																																								
C	2011	Tahoe	Body	Assist Step Controller																																																								
C	2011	Tahoe	Body	Body Control Module			V																																				V	V																
C	2011	Tahoe	Body	Body Control Module (aux.)																																																								
C	2011	Tahoe	Body	Digital Radio Receiver																																																								
C	2011	Tahoe	Body	Driver Door Switch																																					V	V	V																	
C	2011	Tahoe	Body	HVAC Control Module Auto																																						V		V																
C	2011	Tahoe	Body	HVAC Control Module Manual																																						V		V																
C	2011	Tahoe	Body	Instrument Panel Cluster																																																								
C	2011	Tahoe	Body	Left Side Object Detection Module																																																								
C	2011	Tahoe	Body	Lift Gate Module																																					V																			
C	2011	Tahoe	Body	Memory Seat Module																																																								
C	2011	Tahoe	Body	Park Assist Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2011	Tahoe	Body	Passenger Door Switch																																					V	V	V																
C	2011	Tahoe	Body	Passenger Presence System																																					V																		
C	2011	Tahoe	Body	Radio																																																							
C	2011	Tahoe	Body	Rear Heated Seat Module																																																							
C	2011	Tahoe	Body	Rear HVAC/RSA																																																							
C	2011	Tahoe	Body	Right Side Object Detection Module																																																							
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																							
C	2011	Tahoe	Body	Theft Deterrent Module																																																							
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V		V																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																							
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																							
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																							
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																							
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																							
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																							
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																							
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																							
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																							
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																							
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																							
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																							
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																							
C	2011	Tahoe Hybrid	Body	Body Control Module			V																																			V	V																	
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																							
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																							
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																					V	V	V																	
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																																							
C	2011	Tahoe Hybrid	Body	HVAC Control Module																																						V		V																
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																							
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																							
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																					V																			
C	2011	Tahoe Hybrid	Body	Park Assist Module																																																							
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																					V	V	V																	
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																					V																		
C	2011	Tahoe Hybrid	Body	Radio																																																						
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																							
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																							
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																							
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																							
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																							
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																							
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																V	V																							
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2012	Avalanche	Chassis	Electronic Brake Control Module																																			V																				
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																							
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																							
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2012	Avalanche	Body	Amplifier (Bose)																																																								
C	2012	Avalanche	Body	Assist Step Controller																																																								
C	2012	Avalanche	Body	Body Control Module			V																																			V	V																	
C	2012	Avalanche	Body	Body Control Module (aux.)																																																								
C	2012	Avalanche	Body	Digital Radio Receiver																																																								
C	2012	Avalanche	Body	Driver Door Switch																																					V	V	V																	
C	2012	Avalanche	Body	HVAC Control Module Auto																																						V		V																
C	2012	Avalanche	Body	HVAC Control Module Manual																																						V		V																
C	2012	Avalanche	Body	Instrument Panel Cluster																																																								
C	2012	Avalanche	Body	Memory Seat Module																																																								
C	2012	Avalanche	Body	Navigation Radio																																																								
C	2012	Avalanche	Body	Park Assist Module																																																								
C	2012	Avalanche	Body	Passenger Door Switch																																					V	V	V																	
C	2012	Avalanche	Body	Passenger Presence System																																					V																			
C	2012	Avalanche	Body	Radio																																																								
C	2012	Avalanche	Body	Rear Heated Seat Module																																																								
C	2012	Avalanche	Body	Rear HVAC/RSA																																																								
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																								
C	2012	Avalanche	Body	Theft Deterrent Module																																																								
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																								
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																								
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																								
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																								
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																								
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																								
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																								
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																								
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																								
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																								
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																								
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																								
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																								
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																								
C	2012	Captiva	Chassis	Parking Brake Control Module																																																								
C	2012	Captiva	Body	Body Control Module																																																								
C	2012	Captiva	Body	Auxiliary Body Control Module																																																								
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2012	Captiva	Body	Instrument Cluster																																																								
C	2012	Captiva	Body	Headlamp Control Module																																																								
C	2012	Captiva	Body	HVAC Control Module																																																								
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																								
C	2012	Captiva	Body	Parking Assist Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2012	Captiva	Body	Theft Deterrent Module																																																								
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																											V		V	V																										
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																											V		V	V																										
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																						
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																			V																					
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																							
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																							
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																							
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																							
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																							
C	2012	Cheyenne	Body	Amplifier (Bose)																																																							
C	2012	Cheyenne	Body	Body Control Module			V																																			V	V																	
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																							
C	2012	Cheyenne	Body	Digital Radio Receiver																																																							
C	2012	Cheyenne	Body	Driver Door Switch																																					V	V	V																	
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																							
C	2012	Cheyenne	Body	Park Assist Module																																																							
C	2012	Cheyenne	Body	Passenger Door Switch																																					V	V	V																	
C	2012	Cheyenne	Body	Passenger Presence System																																					V																			
C	2012	Cheyenne	Body	Rear Heated Seat Module																																																							
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																							
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																							
C	2012	Cheyenne	Body	Theft Deterrent Module																																																							
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																						
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																														V																										
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																											V		V	V																										
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
C	2012	Suburban	Chassis	EBCM Under 8600 GVW																																			V																					
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																							
C	2012	Suburban	Chassis	Electronic Suspension Control																																																							
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																							
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																							
C	2012	Suburban	Body	Amplifier (Bose)																																																							
C	2012	Suburban	Body	Assist Step Controller																																																							
C	2012	Suburban	Body	Body Control Module			V																																			V	V																	
C	2012	Suburban	Body	Body Control Module (aux.)																																																							
C	2012	Suburban	Body	Digital Radio Receiver																																																							
C	2012	Suburban	Body	Driver Door Switch																																					V	V	V																	
C	2012	Suburban	Body	HVAC Control Module Auto																																						V		V																
C	2012	Suburban	Body	HVAC Control Module Manual																																						V		V																
C	2012	Suburban	Body	Instrument Panel Cluster																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2012	Suburban	Body	Left Side Object Detection Module																																																								
C	2012	Suburban	Body	Lift Gate Module																																				V																				
C	2012	Suburban	Body	Memory Seat Module																																																							
C	2012	Suburban	Body	Navigation Radio																																																							
C	2012	Suburban	Body	Park Assist Module																																																							
C	2012	Suburban	Body	Passenger Door Switch																																				V	V	V																		
C	2012	Suburban	Body	Passenger Presence System																																				V																			
C	2012	Suburban	Body	Radio																																																							
C	2012	Suburban	Body	Rear Heated Seat Module																																																							
C	2012	Suburban	Body	Rear HVAC/RSA																																																							
C	2012	Suburban	Body	Right Side Object Detection Module																																																							
C	2012	Suburban	Body	Supplemental Inflatable Restraint																																																							
C	2012	Suburban	Body	Theft Deterrent Module																																																							
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																											V		V	V																										
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																											V		V	V																										
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																							
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																							
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																						
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																											V		V	V																										
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																											V		V	V																										
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																							
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																											V			V																										
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																							
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																							
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																				V	V	V	V	V																															
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																							
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																							
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																				V	V	V	V	V																															
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																			V																					
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																							
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																							
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																							
C	2012	Silverado	Chassis	Electronic Suspension Control																																																							
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																							
C	2012	Silverado	Body	Amplifier (Bose)																																																							
C	2012	Silverado	Body	Body Control Module			V																																			V	V																
C	2012	Silverado	Body	Body Control Module (aux.)																																																							
C	2012	Silverado	Body	Digital Radio Receiver																																																							
C	2012	Silverado	Body	Driver Door Switch																																				V	V	V																	
C	2012	Silverado	Body	HVAC Control Module Auto																																						V		V															

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2012	Silverado	Body	HVAC Control Module Manual																																						V		V																
C	2012	Silverado	Body	Instrument Panel Cluster																																																							
C	2012	Silverado	Body	Memory Seat Module																																																							
C	2012	Silverado	Body	Navigation Radio																																																							
C	2012	Silverado	Body	Park Assist Module																																																							
C	2012	Silverado	Body	Passenger Door Switch																																				V	V	V																		
C	2012	Silverado	Body	Passenger Presence System																																				V																			
C	2012	Silverado	Body	Radio																																																							
C	2012	Silverado	Body	Rear Heated Seat Module																																																							
C	2012	Silverado	Body	Rear HVAC/RSA																																																							
C	2012	Silverado	Body	Supplemental Inflatable Restraint																																																							
C	2012	Silverado	Body	Theft Deterrent Module																																																							
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V		V																												
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																							
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																							
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																							
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																							
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																							
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																							
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																							
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																							
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																							
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																							
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																							
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																							
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																							
C	2012	Silverado Hybrid	Body	Body Control Module			V																																			V	V																	
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																							
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																							
C	2012	Silverado Hybrid	Body	Driver Door Switch																																				V	V	V																		
C	2012	Silverado Hybrid	Body	Heated Seat Module																																																							
C	2012	Silverado Hybrid	Body	HVAC Control Module																																						V		V																	
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																							
C	2012	Silverado Hybrid	Body	Navigation Radio																																																							
C	2012	Silverado Hybrid	Body	Park Assist Module																																																							
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																				V	V	V																		
C	2012	Silverado Hybrid	Body	Passenger Presence System																																				V																			
C	2012	Silverado Hybrid	Body	Radio																																																							
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																							
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																							
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																							
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																							
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																							
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																													V																											
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2012	Tahoe	Chassis	Electronic Brake Control Module																																		V																					
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																							
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																							
C	2012	Tahoe	Body	Amplifier (Bose)																																																							
C	2012	Tahoe	Body	Assist Step Controller																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2012	Tahoe	Body	Body Control Module			V																																			V	V																
C	2012	Tahoe	Body	Body Control Module (aux.)																																																							
C	2012	Tahoe	Body	Digital Radio Receiver																																																							
C	2012	Tahoe	Body	Driver Door Switch																																				V	V	V																	
C	2012	Tahoe	Body	HVAC Control Module Auto																																					V		V																
C	2012	Tahoe	Body	HVAC Control Module Manual																																					V		V																
C	2012	Tahoe	Body	Instrument Panel Cluster																																																						
C	2012	Tahoe	Body	Left Side Object Detection Module																																																						
C	2012	Tahoe	Body	Lift Gate Module																																				V																			
C	2012	Tahoe	Body	Memory Seat Module																																																						
C	2012	Tahoe	Body	Navigation Radio																																																						
C	2012	Tahoe	Body	Park Assist Module																																																						
C	2012	Tahoe	Body	Passenger Door Switch																																				V	V	V																	
C	2012	Tahoe	Body	Passenger Presence System																																				V																			
C	2012	Tahoe	Body	Radio																																																						
C	2012	Tahoe	Body	Rear Heated Seat Module																																																						
C	2012	Tahoe	Body	Rear HVAC/RSA																																																						
C	2012	Tahoe	Body	Right Side Object Detection Module																																																						
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																						
C	2012	Tahoe	Body	Theft Deterrent Module																																																						
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V		V																											
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																						
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																						
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																						
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																						
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																						
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																						
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																						
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																						
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																						
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																						
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																						
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																						
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																						
C	2012	Tahoe Hybrid	Body	Body Control Module			V																																			V	V																
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																						
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																						
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																				V	V	V																	
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																																						
C	2012	Tahoe Hybrid	Body	HVAC Control Module																																						V		V																
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																						
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																						
C	2012	Tahoe Hybrid	Body	Lift Gate Module																																				V																			
C	2012	Tahoe Hybrid	Body	Navigation Radio																																																						
C	2012	Tahoe Hybrid	Body	Park Assist Module																																																						
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																				V	V	V																	
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																				V																			
C	2012	Tahoe Hybrid	Body	Radio																																																						
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																						
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																						
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																V	V																							
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2013	Avalanche	Chassis	Electronic Brake Control Module																																			V																					
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																								
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Avalanche	Body	Amplifier (Bose)																																																								
C	2013	Avalanche	Body	Assist Step Controller																																																								
C	2013	Avalanche	Body	Body Control Module			V																																			V	V																	
C	2013	Avalanche	Body	Body Control Module (aux.)																																																								
C	2013	Avalanche	Body	Digital Radio Receiver																																																								
C	2013	Avalanche	Body	Driver Door Switch																																					V	V	V																	
C	2013	Avalanche	Body	HVAC Control Module Auto																																						V		V																
C	2013	Avalanche	Body	HVAC Control Module Manual																																						V		V																
C	2013	Avalanche	Body	Instrument Panel Cluster																																																								
C	2013	Avalanche	Body	Memory Seat Module																																																								
C	2013	Avalanche	Body	Navigation Radio																																																								
C	2013	Avalanche	Body	Park Assist Module																																																								
C	2013	Avalanche	Body	Passenger Door Switch																																					V	V	V																	
C	2013	Avalanche	Body	Passenger Presence System																																					V																			
C	2013	Avalanche	Body	Radio																																																								
C	2013	Avalanche	Body	Rear Heated Seat Module																																																								
C	2013	Avalanche	Body	Rear HVAC/RSA																																																								
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																								
C	2013	Avalanche	Body	Theft Deterrent Module																																																								
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																								
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																								
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																								
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																								
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																								
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																								
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																								
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																								
C	2013	Captiva	Chassis	Electronic Brake Control Module																																																								
C	2013	Captiva	Chassis	Parking Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																									
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																										
C	2013	Captiva	Body	Auxiliary Body Control Module																																																										
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2013	Captiva	Body	Instrument Cluster																																																										
C	2013	Captiva	Body	Headlamp Control Module																																																										
C	2013	Captiva	Body	HVAC Control Module																																																										
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
C	2013	Captiva	Body	Theft Deterrent Module																																																										
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																											V		V	V																												
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																											V		V	V																												
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																												
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																								
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																			V																							
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																										
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Cheyenne	Body	Amplifier (Bose)																																																										
C	2013	Cheyenne	Body	Body Control Module			V																																			V	V																		
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2013	Cheyenne	Body	Digital Radio Receiver																																																										
C	2013	Cheyenne	Body	Driver Door Switch																																					V	V	V																		
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2013	Cheyenne	Body	Park Assist Module																																																										
C	2013	Cheyenne	Body	Passenger Door Switch																																					V	V	V																		
C	2013	Cheyenne	Body	Passenger Presence System																																					V																				
C	2013	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2013	Cheyenne	Body	Theft Deterrent Module																																																										
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																												
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																								
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																														V																												
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																											V		V	V																												
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																								
C	2013	Suburban	Chassis	EBCM Under 8600 GVW																																			V																							
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2013	Suburban	Chassis	Electronic Suspension Control																																																										
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Suburban	Body	Amplifier (Bose)																																																										
C	2013	Suburban	Body	Assist Step Controller																																																										
C	2013	Suburban	Body	Body Control Module			V																																			V	V																		
C	2013	Suburban	Body	Body Control Module (aux.)																																																										
C	2013	Suburban	Body	Digital Radio Receiver																																																										
C	2013	Suburban	Body	Driver Door Switch																																				V	V	V																				
C	2013	Suburban	Body	HVAC Control Module Auto																																						V		V																		
C	2013	Suburban	Body	HVAC Control Module Manual																																						V		V																		
C	2013	Suburban	Body	Instrument Panel Cluster																																																										
C	2013	Suburban	Body	Left Side Object Detection Module																																																										
C	2013	Suburban	Body	Lift Gate Module																																				V																						
C	2013	Suburban	Body	Memory Seat Module																																																										
C	2013	Suburban	Body	Navigation Radio																																																										
C	2013	Suburban	Body	Park Assist Module																																																										
C	2013	Suburban	Body	Passenger Door Switch																																				V	V	V																				
C	2013	Suburban	Body	Passenger Presence System																																				V																						
C	2013	Suburban	Body	Radio																																																										
C	2013	Suburban	Body	Rear Heated Seat Module																																																										
C	2013	Suburban	Body	Rear HVAC/RSA																																																										
C	2013	Suburban	Body	Right Side Object Detection Module																																																										
C	2013	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2013	Suburban	Body	Theft Deterrent Module																																																										
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																											V		V	V																												
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																											V		V	V																												
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																												
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																								
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																												
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																								
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																											V		V	V																												
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																											V		V	V																												
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																								
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																												
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																	V	V																								
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																												
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																								
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																											V			V																												
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																				V	V	V	V	V																																		
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																			V																						
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
C	2013	Silverado	Chassis	Electronic Suspension Control																																																										
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2013	Silverado	Body	Amplifier (Bose)																																																										
C	2013	Silverado	Body	Body Control Module			V																																			V	V																		
C	2013	Silverado	Body	Body Control Module (aux.)																																																										
C	2013	Silverado	Body	Digital Radio Receiver																																																										
C	2013	Silverado	Body	Driver Door Switch																																					V	V	V																			
C	2013	Silverado	Body	HVAC Control Module Auto																																						V		V																		
C	2013	Silverado	Body	HVAC Control Module Manual																																						V		V																		
C	2013	Silverado	Body	Instrument Panel Cluster																																																										
C	2013	Silverado	Body	Memory Seat Module																																																										
C	2013	Silverado	Body	Navigation Radio																																																										
C	2013	Silverado	Body	Park Assist Module																																																										
C	2013	Silverado	Body	Passenger Door Switch																																					V	V	V																			
C	2013	Silverado	Body	Passenger Presence System																																					V																					
C	2013	Silverado	Body	Radio																																																										
C	2013	Silverado	Body	Rear Heated Seat Module																																																										
C	2013	Silverado	Body	Rear HVAC/RSA																																																										
C	2013	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2013	Silverado	Body	Theft Deterrent Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V		V																														
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2013	Silverado Hybrid	Body	Body Control Module			V																																			V	V																		
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2013	Silverado Hybrid	Body	Driver Door Switch																																					V	V	V																			
C	2013	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2013	Silverado Hybrid	Body	HVAC Control Module																																						V		V																		
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2013	Silverado Hybrid	Body	Navigation Radio																																																										
C	2013	Silverado Hybrid	Body	Park Assist Module																																																										
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																					V	V	V																			
C	2013	Silverado Hybrid	Body	Passenger Presence System																																					V																					
C	2013	Silverado Hybrid	Body	Radio																																																										
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																								
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																													V																												
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2013	Tahoe	Chassis	Electronic Brake Control Module																																		V																						
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																								
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Tahoe	Body	Amplifier (Bose)																																																								
C	2013	Tahoe	Body	Assist Step Controller																																																								
C	2013	Tahoe	Body	Body Control Module			V																																			V	V																	
C	2013	Tahoe	Body	Body Control Module (aux.)																																																								
C	2013	Tahoe	Body	Digital Radio Receiver																																																								
C	2013	Tahoe	Body	Driver Door Switch																																					V	V	V																	
C	2013	Tahoe	Body	HVAC Control Module Auto																																						V		V																
C	2013	Tahoe	Body	HVAC Control Module Manual																																						V		V																
C	2013	Tahoe	Body	Instrument Panel Cluster																																																								
C	2013	Tahoe	Body	Left Side Object Detection Module																																																								
C	2013	Tahoe	Body	Lift Gate Module																																					V																			
C	2013	Tahoe	Body	Memory Seat Module																																																								
C	2013	Tahoe	Body	Navigation Radio																																																								
C	2013	Tahoe	Body	Park Assist Module																																																								
C	2013	Tahoe	Body	Passenger Door Switch																																					V	V	V																	
C	2013	Tahoe	Body	Passenger Presence System																																					V																			
C	2013	Tahoe	Body	Radio																																																								
C	2013	Tahoe	Body	Rear Heated Seat Module																																																								
C	2013	Tahoe	Body	Rear HVAC/RSA																																																								
C	2013	Tahoe	Body	Right Side Object Detection Module																																																								
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																								
C	2013	Tahoe	Body	Theft Deterrent Module																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V		V																												
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
C	2013	Tahoe Hybrid	Body	Body Control Module			V																																			V	V																	
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																					V	V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																																								
C	2013	Tahoe Hybrid	Body	HVAC Control Module																																						V		V																	
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
C	2013	Tahoe Hybrid	Body	Lift Gate Module																																					V																				
C	2013	Tahoe Hybrid	Body	Navigation Radio																																																									
C	2013	Tahoe Hybrid	Body	Park Assist Module																																																									
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																					V	V	V																		
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																					V																				
C	2013	Tahoe Hybrid	Body	Radio																																																									
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																									
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																									
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																									
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																									
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																									
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																									
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																									
C	2014	Captiva (3GN)	Body	Body Control Module																																																									
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2014	Captiva (3GN)	Body	Passenger Presence Module																																																									
C	2014	Captiva (3GN)	Body	Instrument Cluster																																																									
C	2014	Captiva (3GN)	Body	Radio																																																									
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																									
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																									
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																									
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2014	Captiva (3GN)	Body	HVAC Control Module																																																									
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																									
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																									
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																									
C	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																									
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																									
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																									
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																									
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																									
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																									
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																									
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																										
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Captiva (Other)	Body	Instrument Cluster																																																										
C	2014	Captiva (Other)	Body	Headlamp Control Module																																																										
C	2014	Captiva (Other)	Body	HVAC Control Module																																																										
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
C	2014	Captiva (Other)	Body	Theft Deterrent Module																																																										
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																										
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																										
C	2014	Cheyenne	Chassis	Power Steering Control Module																																																										
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Cheyenne	Body	Body Control Module																																																										
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Cheyenne	Body	Passenger Presence Module																																																										
C	2014	Cheyenne	Body	Instrument Cluster																																																										
C	2014	Cheyenne	Body	Radio Control																																																										
C	2014	Cheyenne	Body	HVAC Control																																																										
C	2014	Cheyenne	Body	Radio																																																										
C	2014	Cheyenne	Body	Amplifier																																																										
C	2014	Cheyenne	Body	Media Disc Player																																																										
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																										
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
C	2014	Cheyenne	Body	HVAC Control Module																																																										
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																										
C	2014	Cheyenne	Body	Parking Assist Control Module																																																										
C	2014	Cheyenne	Body	Frontview Camera Module																																																										
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado	Chassis	Parking Brake Control Module																																																										
C	2014	Silverado	Chassis	Power Steering Control Module																																																										
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Silverado	Body	Body Control Module																																																										
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado	Body	Passenger Presence Module																																																										
C	2014	Silverado	Body	Instrument Cluster																																																										
C	2014	Silverado	Body	Radio Control																																																										
C	2014	Silverado	Body	HVAC Control																																																										
C	2014	Silverado	Body	Radio																																																										
C	2014	Silverado	Body	Amplifier																																																										
C	2014	Silverado	Body	Media Disc Player																																																										
C	2014	Silverado	Body	Human Machine Interface Control Module																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2014	Silverado	Body	Parking Assist Control Module																																																										
C	2014	Silverado	Body	Frontview Camera Module																																																										
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																										
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Suspension Control Module																																																										
C	2014	Silverado HD	Body	Body Control Module																																																										
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado HD	Body	Passenger Presence Module																																																										
C	2014	Silverado HD	Body	Instrument Cluster																																																										
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
C	2014	Silverado HD	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2014	Silverado HD	Body	Navigation Radio																																																								
C	2014	Silverado HD	Body	Uplevel Radio																																																								
C	2014	Silverado HD	Body	Amplifier																																																								
C	2014	Silverado HD	Body	Rear Audio Control Module																																																								
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																								
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																								
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																								
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																								
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																								
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																								
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																								
C	2014	Silverado HD	Body	Seat Memory Control Module																																																								
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																								
C	2014	Silverado HD	Body	Parking Assist Control Module																																																								
C	2014	Silverado HD	Body	Theft Deterrent Module																																																								
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																								
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																								
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																								
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																								
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																								
C	2014	Suburban	Chassis	Parking Brake Control Module																																																								
C	2014	Suburban	Chassis	Suspension Control Module																																																								
C	2014	Suburban	Body	Body Control Module																																																								
C	2014	Suburban	Body	Auxiliary Body Control Module																																																								
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Suburban	Body	Passenger Presence Module																																																								
C	2014	Suburban	Body	Instrument Cluster																																																								
C	2014	Suburban	Body	Base Radio																																																								
C	2014	Suburban	Body	Navigation Radio																																																								
C	2014	Suburban	Body	Uplevel Radio																																																								
C	2014	Suburban	Body	Amplifier																																																								
C	2014	Suburban	Body	Rear Audio Control Module																																																								
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																								
C	2014	Suburban	Body	Personal Audio Link Control Module																																																								
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																								
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																								
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																								
C	2014	Suburban	Body	Liftgate Control Module																																																								
C	2014	Suburban	Body	Seat Memory Control Module																																																								
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2014	Suburban	Body	Assist Step Control Module																																																								
C	2014	Suburban	Body	Right Side Object Detection Control Module																																																									
C	2014	Suburban	Body	Left Side Object Detection Control Module																																																									
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																									
C	2014	Suburban	Body	Parking Assist Control Module																																																									
C	2014	Suburban	Body	Theft Deterrent Module																																																									
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																									
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																									
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																									
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																									
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																									
C	2014	Tahoe	Chassis	Suspension Control Module																																																									
C	2014	Tahoe	Body	Body Control Module																																																									
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																									
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2014	Tahoe	Body	Passenger Presence Module																																																									
C	2014	Tahoe	Body	Instrument Cluster																																																									
C	2014	Tahoe	Body	Base Radio																																																									
C	2014	Tahoe	Body	Navigation Radio																																																									
C	2014	Tahoe	Body	Uplevel Radio																																																									
C	2014	Tahoe	Body	Amplifier																																																									
C	2014	Tahoe	Body	Rear Audio Control Module																																																									
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																									
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																									
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																									
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																									
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																									
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																									
C	2014	Tahoe	Body	Liftgate Control Module																																																									
C	2014	Tahoe	Body	Seat Memory Control Module																																																									
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																																									
C	2014	Tahoe	Body	Assist Step Control Module																																																									
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																																									
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																																									
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																									
C	2014	Tahoe	Body	Parking Assist Control Module																																																									
C	2014	Tahoe	Body	Theft Deterrent Module																																																									
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																									
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																									
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2015	Captiva (3GN)	Body	Body Control Module																																																								
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																																								
C	2015	Captiva (3GN)	Body	Instrument Cluster																																																								
C	2015	Captiva (3GN)	Body	Radio																																																								
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																								
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																								
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																								
C	2015	Captiva (3GN)	Body	HVAC Control Module																																																								
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																								
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																								
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																								
C	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																								
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																								
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																								
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																								
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																								
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																								
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																								
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																								
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																								
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																								
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																								
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2015	Captiva (Other)	Body	Instrument Cluster																																																								
C	2015	Captiva (Other)	Body	Headlamp Control Module																																																								
C	2015	Captiva (Other)	Body	HVAC Control Module																																																								
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																								
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																								
C	2015	Captiva (Other)	Body	Theft Deterrent Module																																																								
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																								
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																									
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																										
C	2015	Cheyenne	Chassis	Power Steering Control Module																																																										
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Cheyenne	Chassis	Suspension Control Module																																																										
C	2015	Cheyenne	Body	Body Control Module																																																										
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Cheyenne	Body	Passenger Presence Module																																																										
C	2015	Cheyenne	Body	Instrument Cluster																																																										
C	2015	Cheyenne	Body	Radio Controls																																																										
C	2015	Cheyenne	Body	HVAC Controls																																																										
C	2015	Cheyenne	Body	Radio																																																										
C	2015	Cheyenne	Body	Amplifier																																																										
C	2015	Cheyenne	Body	Media Disc Player																																																										
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																										
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
C	2015	Cheyenne	Body	HVAC Control Module																																																										
C	2015	Cheyenne	Body	Parking Assist Control Module																																																										
C	2015	Cheyenne	Body	Frontview Camera Module																																																										
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Silverado	Chassis	Power Steering Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2015	Silverado	Chassis	Suspension Control Module																																																										
C	2015	Silverado	Body	Body Control Module																																																										
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Silverado	Body	Passenger Presence Module																																																										
C	2015	Silverado	Body	Instrument Cluster																																																										
C	2015	Silverado	Body	Radio Controls																																																										
C	2015	Silverado	Body	HVAC Controls																																																										
C	2015	Silverado	Body	Radio																																																										
C	2015	Silverado	Body	Amplifier																																																										
C	2015	Silverado	Body	Media Disc Player																																																										
C	2015	Silverado	Body	Human Machine Interface Control Module																																																											
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																											
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
C	2015	Silverado	Body	Parking Assist Control Module																																																											
C	2015	Silverado	Body	Frontview Camera Module																																																											
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																											
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2015	Suburban	Chassis	Electronic Brake Control Module																																																											
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																											
C	2015	Suburban	Chassis	Parking Brake Control Module																																																											
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2015	Suburban	Chassis	Power Steering Control Module																																																											
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Suburban	Chassis	Suspension Control Module																																																											
C	2015	Suburban	Body	Body Control Module																																																											
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Suburban	Body	Passenger Presence Module																																																											
C	2015	Suburban	Body	Instrument Cluster																																																											
C	2015	Suburban	Body	Radio Controls																																																										
C	2015	Suburban	Body	HVAC Controls																																																										
C	2015	Suburban	Body	Radio																																																										
C	2015	Suburban	Body	Amplifier																																																										
C	2015	Suburban	Body	Media Disc Player																																																										
C	2015	Suburban	Body	Human Machine Interface Control Module																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2015	Suburban	Body	HVAC Control Module																																																											
C	2015	Suburban	Body	Liftgate Control Module																																																											
C	2015	Suburban	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2015	Suburban	Body	Assist Step Control Module																																																								
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																									
C	2015	Suburban	Body	Parking Assist Control Module																																																									
C	2015	Suburban	Body	Frontview Camera Module																																																									
C	2015	Suburban	Body	Steering Column Lock Control Module																																																									
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																									
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																									
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																									
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																									
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																									
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																																									
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																									
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																									
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																									
C	2015	Tahoe	Chassis	Power Steering Control Module																																																									
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2015	Tahoe	Chassis	Suspension Control Module																																																									
C	2015	Tahoe	Body	Body Control Module																																																									
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	Tahoe	Body	Passenger Presence Module																																																									
C	2015	Tahoe	Body	Instrument Cluster																																																									
C	2015	Tahoe	Body	Radio Controls																																																									
C	2015	Tahoe	Body	HVAC Controls																																																									
C	2015	Tahoe	Body	Radio																																																									
C	2015	Tahoe	Body	Amplifier																																																									
C	2015	Tahoe	Body	Media Disc Player																																																									
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																									
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																									
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																									
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2015	Tahoe	Body	HVAC Control Module																																																									
C	2015	Tahoe	Body	Liftgate Control Module																																																									
C	2015	Tahoe	Body	Keyless Entry Control Module																																																									
C	2015	Tahoe	Body	Assist Step Control Module																																																									
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																									
C	2015	Tahoe	Body	Parking Assist Control Module																																																									
C	2015	Tahoe	Body	Frontview Camera Module																																																									
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																									
C	2015	Tahoe	Body	Battery Energy Control Module																																																									
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																									
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
C	2016	Captiva (3GN)	Body	Body Control Module																																																										
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																										
C	2016	Captiva (3GN)	Body	Radio																																																										
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																										
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																										
C	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																										
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																										
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Captiva (Other)	Body	Instrument Cluster																																																										
C	2016	Captiva (Other)	Body	Headlamp Control Module																																																										
C	2016	Captiva (Other)	Body	Radio																																																										
C	2016	Captiva (Other)	Body	HVAC Control Module																																																										
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																										
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																										
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
C	2016	Captiva (Other)	Body	Theft Deterrent Module																																																										
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																										
C	2016	Cheyenne	Chassis	Power Steering Control Module																																																										
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Cheyenne	Chassis	Suspension Control Module																																																										
C	2016	Cheyenne	Body	Body Control Module																																																										
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Cheyenne	Body	Passenger Presence Module																																																										
C	2016	Cheyenne	Body	Instrument Cluster																																																										
C	2016	Cheyenne	Body	Radio Controls																																																										
C	2016	Cheyenne	Body	HVAC Controls																																																										
C	2016	Cheyenne	Body	Radio																																																										
C	2016	Cheyenne	Body	Amplifier																																																										
C	2016	Cheyenne	Body	Media Disc Player																																																										
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																										
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
C	2016	Cheyenne	Body	HVAC Control Module																																																										
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																										
C	2016	Cheyenne	Body	Parking Assist Control Module																																																										
C	2016	Cheyenne	Body	Frontview Camera Module																																																										
C	2016	Cheyenne	Body	Frontview Camera Module																																																										
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Silverado	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2016	Silverado	Chassis	Power Steering Control Module																																																								
C	2016	Silverado	Chassis	Power Steering Control Module																																																									
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2016	Silverado	Chassis	Suspension Control Module																																																									
C	2016	Silverado	Body	Body Control Module																																																									
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Silverado	Body	Passenger Presence Module																																																									
C	2016	Silverado	Body	Instrument Cluster																																																									
C	2016	Silverado	Body	Radio Controls																																																									
C	2016	Silverado	Body	HVAC Controls																																																									
C	2016	Silverado	Body	Radio (IO3)																																																									
C	2016	Silverado	Body	Radio (IOB)																																																									
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																									
C	2016	Silverado	Body	Amplifier																																																									
C	2016	Silverado	Body	Media Disc Player																																																									
C	2016	Silverado	Body	Human Machine Interface Control Module																																																									
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																									
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																									
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																									
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																									
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																									
C	2016	Silverado	Body	Parking Assist Control Module																																																									
C	2016	Silverado	Body	Frontview Camera Module																																																									
C	2016	Silverado	Body	Frontview Camera Module																																																									
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2016	Suburban	Chassis	Electronic Brake Control Module																																																									
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																									
C	2016	Suburban	Chassis	Parking Brake Control Module																																																									
C	2016	Suburban	Chassis	Power Steering Control Module																																																									
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2016	Suburban	Chassis	Suspension Control Module																																																									
C	2016	Suburban	Body	Body Control Module																																																									
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Suburban	Body	Passenger Presence Module																																																									
C	2016	Suburban	Body	Instrument Cluster																																																									
C	2016	Suburban	Body	Radio Controls																																																									
C	2016	Suburban	Body	HVAC Controls																																																									
C	2016	Suburban	Body	Radio																																																									
C	2016	Suburban	Body	Amplifier																																																									
C	2016	Suburban	Body	Media Disc Player																																																									
C	2016	Suburban	Body	Human Machine Interface Control Module																																																									
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																																									
C	2016	Suburban	Body	HVAC Control Module																																																									
C	2016	Suburban	Body	Liftgate Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																								
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																								
C	2016	Suburban	Body	Keyless Entry Control Module																																																								
C	2016	Suburban	Body	Assist Step Control Module																																																								
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																								
C	2016	Suburban	Body	Parking Assist Control Module																																																								
C	2016	Suburban	Body	Frontview Camera Module																																																								
C	2016	Suburban	Body	Steering Column Lock Control Module																																																								
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																																								
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																								
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																								
C	2016	Tahoe	Chassis	Power Steering Control Module																																																								
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2016	Tahoe	Chassis	Suspension Control Module																																																								
C	2016	Tahoe	Body	Body Control Module																																																								
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2016	Tahoe	Body	Passenger Presence Module																																																								
C	2016	Tahoe	Body	Instrument Cluster																																																								
C	2016	Tahoe	Body	Radio Controls																																																								
C	2016	Tahoe	Body	HVAC Controls																																																								
C	2016	Tahoe	Body	Radio																																																								
C	2016	Tahoe	Body	Amplifier																																																								
C	2016	Tahoe	Body	Media Disc Player																																																								
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																								
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																								
C	2016	Tahoe	Body	HVAC Control Module																																																								
C	2016	Tahoe	Body	Liftgate Control Module																																																								
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																								
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																								
C	2016	Tahoe	Body	Keyless Entry Control Module																																																								
C	2016	Tahoe	Body	Assist Step Control Module																																																								
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																								
C	2016	Tahoe	Body	Parking Assist Control Module																																																								
C	2016	Tahoe	Body	Frontview Camera Module																																																								
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																								
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																								
E	2004	ALL	Chassis	Electronic Brake Control Module																																																								
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
E	2006	ALL	Chassis	Electronic Brake Control Module																																																								
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
E	2007	ALL	Chassis	Electronic Brake Control Module																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM												V	V																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM															V	V	V		V	V	V																																			
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM												V	V																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM															V	V	V		V	V	V																																			

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																												
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																				
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																												
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																				
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																												
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																				
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																				
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																				
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																											
G	2004	Express/Savana	Chassis	VSES																																																										
G	2004	Express/Savana	Body	Body Control Module																																					V	V	V																				
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2004	Express/Savana	Body	OnStar																																																										
G	2004	Express/Savana	Body	Base Radio																																																										
G	2004	Express/Savana	Body	Uplevel Radio																																																										
G	2004	Express/Savana	Body	Remote Function Actuation																																																										
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																					V	V																				
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																				
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																				
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																												
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																				
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																												
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																				
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																												
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																				
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																				
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																				
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																				
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																																										
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V	V																				
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																												
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																				
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control													V	V																																												
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																				
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control													V	V																																												
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																				
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module													V	V																																												

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																V	V	V		V	V	V																																			
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																								
G	2005	Express/Savana	Chassis	VSES																																																							
G	2005	Express/Savana	Body	Body Control Module																																					V	V	V																	
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																							
G	2005	Express/Savana	Body	Base Radio																																																							
G	2005	Express/Savana	Body	Uplevel Radio																																																							
G	2005	Express/Savana	Body	Remote Function Actuation																																																							
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		V
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																						
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control													V	V																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control													V	V																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module													V	V																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																V	V	V		V	V	V																																		
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																							
G	2005	Express Access/Savana Pro	Chassis	VSES																																																							
G	2005	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																	
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																							
G	2005	Express Access/Savana Pro	Body	Base Radio																																																							
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																							
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																							
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		V
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																						
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control													V	V																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control													V	V																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																V	V	V		V	V	V																																		
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																							
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																							
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																								
G	2006	Express/Savana	Chassis	VSES																																																							
G	2006	Express/Savana	Body	Body Control Module																																					V	V	V																	
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																							
G	2006	Express/Savana	Body	Passenger Presence System																																																						
G	2006	Express/Savana	Body	Base Radio																																																						
G	2006	Express/Savana	Body	Uplevel Radio																																																						
G	2006	Express/Savana	Body	Remote Function Actuation																																																						
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		V
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																						
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																									
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control													V	V																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control													V	V																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																V	V	V		V	V	V																																		
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																							
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																							
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																							
G	2006	Express Access/Savana Pro	Chassis	VSES																																																							
G	2006	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																	
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																						
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																						
G	2006	Express Access/Savana Pro	Body	Base Radio																																																						
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																						
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																						
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		V

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																											
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																			
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control													V	V																																											
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control													V	V																																											
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																											
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																			
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																											
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																											
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																											
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																											
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																											
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																V	V	V		V	V	V																																			
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V	V	V	V																											
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																V	V	V		V	V	V																																			
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2007	Express/Savana	Body	Body Control Module																																				V	V	V																		
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2007	Express/Savana	Body	Passenger Presence System																																																								
G	2007	Express/Savana	Body	Base Radio																																																								
G	2007	Express/Savana	Body	Uplevel Radio																																																								
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																				V																				V
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																											
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control													V	V																																											
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control													V	V																																											
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																											
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																											
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																											
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																											
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																V	V	V		V	V	V																																		
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																							
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																										V	V	V	V																											
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																V	V	V		V	V	V																																		
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																							
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																							
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2007	Express Access/Savana Pro	Body	Body Control Module																																				V	V	V																		
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																							
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																							
G	2007	Express Access/Savana Pro	Body	Radio																																																							
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																				V																		V
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																							
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																										V		V																												
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V												V																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																										V		V	V																											
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																		
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																											
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V												V																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																										V		V	V																											
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																		
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																							
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																										V			V																											
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																							
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																V	V	V		V	V	V																																		
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																						
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																						
G	2008	Express/Savana	Body	Body Control Module			V																																		V	V																	
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2008	Express/Savana	Body	Passenger Presence System																																				V																		
G	2008	Express/Savana	Body	Radio																																																						
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
G	2008	Express/Savana	Body	Rollover Sensor																																																						
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																				V																		
G	2008	Express/Savana	Body	Theft Deterrent Module																																																						
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																										V		V																												
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V												V																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																										V		V	V																											
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																		
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																											
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V												V																								
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																										V		V	V																											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																										V			V																												
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																V	V	V		V	V	V																																			
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2008	Express Access/Savana Pro	Body	Body Control Module			V																																				V	V																	
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																						V																				
G	2008	Express Access/Savana Pro	Body	Radio																																																									
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																						V																				
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																										V		V																														
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																										V		V	V																												
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																			
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																												
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																								
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																										V		V	V																												
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																			
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																										V			V																												
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																V	V	V		V	V	V																																			
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2009	Express/Savana	Body	Body Control Module			V																																				V	V																	
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2009	Express/Savana	Body	Passenger Presence System																																						V																				
G	2009	Express/Savana	Body	Radio																																																								
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2009	Express/Savana	Body	Rollover Sensor																																																									
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																						V																				
G	2009	Express/Savana	Body	Theft Deterrent Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																										V		V																														
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																										V		V	V																												
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																			
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																												
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																								
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																										V		V	V																												
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																			
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																										V			V																												
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																V	V	V		V	V	V																																			

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2009	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V																	
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																					V																				
G	2009	Express Access/Savana Pro	Body	Radio																																																								
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																				
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																											
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																											
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																							
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																											
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																								
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																											
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																							
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																											
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																	V	V																							
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																											
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																	V	V																							
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2010	Express/Savana	Body	Body Control Module			V																																			V	V																	
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2010	Express/Savana	Body	Passenger Presence System																																					V																				
G	2010	Express/Savana	Body	Radio																																																								
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2010	Express/Savana	Body	Rollover Sensor																																																								
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																				
G	2010	Express/Savana	Body	Theft Deterrent Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																											
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																											
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																							
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																								
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																											
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																							
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																	V	V																							
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																									
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																						
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																	V	V																					
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																					
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																					
G	2010	Express Access/Savana Pro	Body	Body Control Module			V																																				V	V															
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																					
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																					V																		
G	2010	Express Access/Savana Pro	Body	Radio																																																					
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																					
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																					
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																					
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																									
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																						
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																									
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																					
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																									
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																					
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																						
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																									
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																					
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																									
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																	V	V																					
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																					
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																									
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																					
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																	V	V																					
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																					
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																					
G	2011	Express/Savana	Body	Body Control Module			V																																				V	V															
G	2011	Express/Savana	Body	Digital Radio Receiver																																																					
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																					
G	2011	Express/Savana	Body	Passenger Presence System																																					V																		
G	2011	Express/Savana	Body	Radio																																																					
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																					
G	2011	Express/Savana	Body	Rollover Sensor																																																					
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		
G	2011	Express/Savana	Body	Theft Deterrent Module																																																					
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																									
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																						
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																									
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																					
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																									
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																					
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																						
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																									
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																					
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																									
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																	V	V																					
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																					

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																							
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																	V	V																						
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2011	Express Access/Savana Pro	Body	Body Control Module			V																																				V	V																
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																							
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																					V																				
G	2011	Express Access/Savana Pro	Body	Radio																																																							
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																							
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																				
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																							
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																						
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																							
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																										
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																	V	V																						
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																							
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																							
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																	V	V																						
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																						
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																						
G	2012	Express/Savana	Body	Body Control Module			V																																				V	V																
G	2012	Express/Savana	Body	Digital Radio Receiver																																																							
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2012	Express/Savana	Body	Passenger Presence System																																					V																				
G	2012	Express/Savana	Body	Radio																																																							
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
G	2012	Express/Savana	Body	Rollover Sensor																																																							
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																				
G	2012	Express/Savana	Body	Theft Deterrent Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																						
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																							
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																										
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																	V	V																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																										V			V																										
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																V	V																							
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2012	Express Access/Savana Pro	Body	Body Control Module			V																																				V	V																
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																							
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																					V																			
G	2012	Express Access/Savana Pro	Body	Radio																																																							
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																							
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																			
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																							
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																										V		V	V																											
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V										V																								
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																										V		V	V																											
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																							
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																											
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																								
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																										V		V	V																											
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																							
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																										V		V	V																											
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																							
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																							
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																										V			V																											
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																							
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																V	V																							
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2013	Express/Savana	Body	Body Control Module			V																																				V	V																
G	2013	Express/Savana	Body	Digital Radio Receiver																																																							
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2013	Express/Savana	Body	Navigation Radio																																																							
G	2013	Express/Savana	Body	Park Assist Module																																																							
G	2013	Express/Savana	Body	Passenger Presence System																																					V																			
G	2013	Express/Savana	Body	Radio																																																							
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
G	2013	Express/Savana	Body	Rollover Sensor																																																							
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																			
G	2013	Express/Savana	Body	Theft Deterrent Module																																																							
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																										V		V	V																											
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V										V																								
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																										V		V	V																											
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																							
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																											
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																								
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																										V		V	V																											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																										V		V	V																									
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																						
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																					
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																										V			V																									
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																				
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																V	V																						
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																					
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																					
G	2013	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V																	
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																					
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																					
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																					
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																					
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																					V																			
G	2013	Express Access/Savana Pro	Body	Radio																																																					
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																					
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																					
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																			
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																					
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																					
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																					
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																					
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																					
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																					
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																					
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																					
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																					
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																					
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																					
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																					
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																					
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																					
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																					
G	2014	Express	Chassis	Electronic Brake Control Module																																																					
G	2014	Express	Body	Body Control Module																																																					
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																					
G	2014	Express	Body	Passenger Presence Module																																																					
G	2014	Express	Body	Rollover Sensor Module																																																					
G	2014	Express	Body	Instrument Cluster																																																					
G	2014	Express	Body	Chime Alarm Control Module																																																					
G	2014	Express	Body	Base Radio																																																					
G	2014	Express	Body	Navigation Radio																																																					
G	2014	Express	Body	Uplevel Radio																																																					
G	2014	Express	Body	Digital Radio Receiver Control Module																																																					
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																					
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																					
G	2014	Express	Body	Auxiliary Heater Control Module																																																					
G	2014	Express	Body	Remote Control Door Lock Receiver																																																					
G	2014	Express	Body	Parking Assist Control Module																																																					
G	2014	Express	Body	Theft Deterrent Module																																																					

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																									
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																									
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																									
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																									
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																									
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																									
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																									
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
G	2014	Savana	Chassis	Electronic Brake Control Module																																																									
G	2014	Savana	Body	Body Control Module																																																								
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
G	2014	Savana	Body	Passenger Presence Module																																																									
G	2014	Savana	Body	Rollover Sensor Module																																																									
G	2014	Savana	Body	Instrument Cluster																																																									
G	2014	Savana	Body	Chime Alarm Control Module																																																									
G	2014	Savana	Body	Base Radio																																																									
G	2014	Savana	Body	Navigation Radio																																																									
G	2014	Savana	Body	Uplevel Radio																																																									
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																									
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																									
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																									
G	2014	Savana	Body	Auxiliary Heater Control Module																																																									
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																									
G	2014	Savana	Body	Parking Assist Control Module																																																									
G	2014	Savana	Body	Theft Deterrent Module																																																									
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
G	2015	Express	Chassis	Electronic Brake Control Module																																																									
G	2015	Express	Body	Body Control Module																																																									
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
G	2015	Express	Body	Rollover Sensor Module																																																									
G	2015	Express	Body	Instrument Cluster																																																									
G	2015	Express	Body	Digital Radio Receiver Control Module																																																									
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																									
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																									
G	2015	Express	Body	Auxiliary Heater Control Module																																																									
G	2015	Express	Body	Remote Control Door Lock Receiver																																																									
G	2015	Express	Body	Parking Assist Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2015	Express	Body	Theft Deterrent Module																																																								
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
G	2015	Savana	Chassis	Electronic Brake Control Module																																																									
G	2015	Savana	Body	Body Control Module																																																									
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
G	2015	Savana	Body	Rollover Sensor Module																																																									
G	2015	Savana	Body	Instrument Cluster																																																									
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																									
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																									
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																									
G	2015	Savana	Body	Auxiliary Heater Control Module																																																									
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																									
G	2015	Savana	Body	Parking Assist Control Module																																																									
G	2015	Savana	Body	Theft Deterrent Module																																																									
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
G	2016	Express	Chassis	Electronic Brake Control Module																																																									
G	2016	Express	Body	Body Control Module																																																									
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
G	2016	Express	Body	Instrument Cluster																																																									
G	2016	Express	Body	Chime Alarm Control Module																																																									
G	2016	Express	Body	Base Radio																																																									
G	2016	Express	Body	Navigation Radio																																																									
G	2016	Express	Body	Uplevel Radio																																																									
G	2016	Express	Body	Digital Radio Receiver Control Module																																																									
G	2016	Express	Body	Telematics Communication Interface Control Module																																																									
G	2016	Express	Body	Auxiliary Heater Control Module																																																									
G	2016	Express	Body	Remote Control Door Lock Receiver																																																									
G	2016	Express	Body	Parking Assist Control Module																																																									
G	2016	Express	Body	Theft Deterrent Module																																																									
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2016	Savana	Chassis	Electronic Brake Control Module																																																								
G	2016	Savana	Body	Body Control Module																																																								
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
G	2016	Savana	Body	Instrument Cluster																																																								
G	2016	Savana	Body	Chime Alarm Control Module																																																								
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																								
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																								
G	2016	Savana	Body	Auxiliary Heater Control Module																																																								
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																								
G	2016	Savana	Body	Parking Assist Control Module																																																								
G	2016	Savana	Body	Theft Deterrent Module																																																								
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module												V	V																																											
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module														V	V	V		V	V	V																																				
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2004	Express/Savana	Chassis	VSES																																																								
H	2004	Express/Savana	Body	Body Control Module																																					V	V	V																	
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2004	Express/Savana	Body	OnStar																																																								
H	2004	Express/Savana	Body	Base Radio																																																								
H	2004	Express/Savana	Body	Uplevel Radio																																																								
H	2004	Express/Savana	Body	Remote Function Actuation																																																								
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																					V	V																		
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module												V	V																																											
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module														V	V	V		V	V	V																																				
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2004	Express Access/Savana Pro	Chassis	VSES																																																								
H	2004	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																	
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2004	Express Access/Savana Pro	Body	OnStar																																																								
H	2004	Express Access/Savana Pro	Body	Base Radio																																																								
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V	V																		
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control												V	V																																											
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control														V	V	V		V	V	V																																				
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control												V	V																																											
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control														V	V	V		V	V	V																																				
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2005	Express/Savana	Chassis	VSES																																																								
H	2005	Express/Savana	Body	Body Control Module																																					V	V	V																	
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2005	Express/Savana	Body	Base Radio																																																								
H	2005	Express/Savana	Body	Uplevel Radio																																																								
H	2005	Express/Savana	Body	Remote Function Actuation																																																								
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																			V

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2005	Express Access/Savana Pro	Chassis	VSES																																																								
H	2005	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																		
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2005	Express Access/Savana Pro	Body	Base Radio																																																								
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		V
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2006	Express/Savana	Chassis	VSES																																																								
H	2006	Express/Savana	Body	Body Control Module																																					V	V	V																		
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2006	Express/Savana	Body	Passenger Presence System																																																								
H	2006	Express/Savana	Body	Base Radio																																																								
H	2006	Express/Savana	Body	Uplevel Radio																																																								
H	2006	Express/Savana	Body	Remote Function Actuation																																																								
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		V
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2006	Express Access/Savana Pro	Chassis	VSES																																																								
H	2006	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																		
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2006	Express Access/Savana Pro	Body	Base Radio																																																								
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		V
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																										
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																		
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2007	Express/Savana	Body	Body Control Module																																					V	V	V																	
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																							
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																							
H	2007	Express/Savana	Body	Passenger Presence System																																																						
H	2007	Express/Savana	Body	Base Radio																																																						
H	2007	Express/Savana	Body	Uplevel Radio																																																						
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		V
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																						
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																									
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																	
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																									
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																	
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																									
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																	
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																							
H	2007	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																	
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																							
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																							
H	2007	Express Access/Savana Pro	Body	Base Radio																																																							
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																							
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		V
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																							
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																											
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V												V																								
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																	
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V												V																								
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																	
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
H	2008	Express/Savana	Body	Body Control Module			V																																			V	V																
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																							
H	2008	Express/Savana	Body	Passenger Presence System																																					V																		
H	2008	Express/Savana	Body	Radio																																																						
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
H	2008	Express/Savana	Body	Rollover Sensor																																																							
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		
H	2008	Express/Savana	Body	Theft Deterrent Module																																																							
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																											
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V												V																								
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V												V																							
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																										V		V	V																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																	
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																						
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																						
H	2008	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V																
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																					V																		
H	2008	Express Access/Savana Pro	Body	Radio																																																						
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																						
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																						
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																										V		V																											
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V										V																							
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																										V		V	V																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																	
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																							
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																										V		V	V																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																	
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																						
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																						
H	2009	Express/Savana	Body	Body Control Module			V																																			V	V																
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																						
H	2009	Express/Savana	Body	Passenger Presence System																																					V																		
H	2009	Express/Savana	Body	Radio																																																						
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
H	2009	Express/Savana	Body	Rollover Sensor																																																						
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		
H	2009	Express/Savana	Body	Theft Deterrent Module																																																						
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																										V		V																											
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V										V																							
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																										V		V	V																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																	
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																							
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																										V		V	V																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																	
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																						
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																						
H	2009	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V																
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																					V																		
H	2009	Express Access/Savana Pro	Body	Radio																																																						
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																							
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																						
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																							
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																						
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
H	2010	Express/Savana	Body	Body Control Module			V																																			V	V																	
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																							
H	2010	Express/Savana	Body	Passenger Presence System																																					V																		
H	2010	Express/Savana	Body	Radio																																																							
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
H	2010	Express/Savana	Body	Rollover Sensor																																																							
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		
H	2010	Express/Savana	Body	Theft Deterrent Module																																																							
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																						
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																						
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																							
H	2010	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V																	
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																					V																		
H	2010	Express Access/Savana Pro	Body	Radio																																																							
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																							
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																							
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																						
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																						
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																										
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																	V	V																						
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
H	2011	Express/Savana	Body	Body Control Module			V																																			V	V																	
H	2011	Express/Savana	Body	Digital Radio Receiver																																																							
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																							
H	2011	Express/Savana	Body	Passenger Presence System																																					V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2011	Express/Savana	Body	Radio																																																								
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2011	Express/Savana	Body	Rollover Sensor																																																								
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																						V																		
H	2011	Express/Savana	Body	Theft Deterrent Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																							
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																							
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																							
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																										
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																							
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2011	Express Access/Savana Pro	Body	Body Control Module			V																																				V	V																
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																						V																		
H	2011	Express Access/Savana Pro	Body	Radio																																																								
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																						V																		
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																							
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																							
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																							
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																										
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																							
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2012	Express/Savana	Body	Body Control Module			V																																				V	V																
H	2012	Express/Savana	Body	Digital Radio Receiver																																																								
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2012	Express/Savana	Body	Passenger Presence System																																						V																		
H	2012	Express/Savana	Body	Radio																																																								
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2012	Express/Savana	Body	Rollover Sensor																																																								
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																						V																		
H	2012	Express/Savana	Body	Theft Deterrent Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																							
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																							
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																										V		V	V																									
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																					
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																					
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																					
H	2012	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V															
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																					
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																					
H	2012	Express Access/Savana Pro	Body	Passenger Presence System																																					V																		
H	2012	Express Access/Savana Pro	Body	Radio																																																					
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																					
H	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																					
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																					
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																										V		V	V																									
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																					
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																									
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																					
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																						
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																										V		V	V																									
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																					
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																										V		V	V																									
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																					
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																					
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																					
H	2013	Express/Savana	Body	Body Control Module			V																																			V	V															
H	2013	Express/Savana	Body	Digital Radio Receiver																																																					
H	2013	Express/Savana	Body	Instrument Panel Cluster																																																					
H	2013	Express/Savana	Body	Navigation Radio																																																					
H	2013	Express/Savana	Body	Park Assist Module																																																					
H	2013	Express/Savana	Body	Passenger Presence System																																					V																		
H	2013	Express/Savana	Body	Radio																																																					
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																					
H	2013	Express/Savana	Body	Rollover Sensor																																																					
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		
H	2013	Express/Savana	Body	Theft Deterrent Module																																																					
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																										V		V	V																									
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																					
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																									
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																					
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																						
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																										V		V	V																									
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																					
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																										V		V	V																									
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																					
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																					
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																					
H	2013	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V															
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																					
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																					
H	2013	Express Access/Savana Pro	Body	Navigation Radio																																																					

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																																									
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																					V																				
H	2013	Express Access/Savana Pro	Body	Radio																																																								
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																				
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																									
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																									
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																									
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																									
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																									
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																									
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																									
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2014	Express	Chassis	Electronic Brake Control Module																																																									
H	2014	Express	Body	Body Control Module																																																									
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
H	2014	Express	Body	Passenger Presence Module																																																									
H	2014	Express	Body	Rollover Sensor Module																																																									
H	2014	Express	Body	Instrument Cluster																																																									
H	2014	Express	Body	Chime Alarm Control Module																																																									
H	2014	Express	Body	Base Radio																																																									
H	2014	Express	Body	Navigation Radio																																																									
H	2014	Express	Body	Uplevel Radio																																																									
H	2014	Express	Body	Digital Radio Receiver Control Module																																																									
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																									
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																									
H	2014	Express	Body	Auxiliary Heater Control Module																																																									
H	2014	Express	Body	Remote Control Door Lock Receiver																																																									
H	2014	Express	Body	Parking Assist Control Module																																																									
H	2014	Express	Body	Theft Deterrent Module																																																									
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																									
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																									
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																									
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																									
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																									
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																									
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																									
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2014	Savana	Chassis	Electronic Brake Control Module																																																										
H	2014	Savana	Body	Body Control Module																																																									
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Savana	Body	Passenger Presence Module																																																										
H	2014	Savana	Body	Rollover Sensor Module																																																										
H	2014	Savana	Body	Instrument Cluster																																																										
H	2014	Savana	Body	Chime Alarm Control Module																																																										
H	2014	Savana	Body	Base Radio																																																										
H	2014	Savana	Body	Navigation Radio																																																										
H	2014	Savana	Body	Uplevel Radio																																																										
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2014	Savana	Body	Auxiliary Heater Control Module																																																										
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2014	Savana	Body	Parking Assist Control Module																																																										
H	2014	Savana	Body	Theft Deterrent Module																																																										
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2015	Express	Chassis	Electronic Brake Control Module																																																										
H	2015	Express	Body	Body Control Module																																																										
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Express	Body	Rollover Sensor Module																																																										
H	2015	Express	Body	Instrument Cluster																																																										
H	2015	Express	Body	Digital Radio Receiver Control Module																																																										
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2015	Express	Body	Auxiliary Heater Control Module																																																										
H	2015	Express	Body	Remote Control Door Lock Receiver																																																										
H	2015	Express	Body	Parking Assist Control Module																																																										
H	2015	Express	Body	Theft Deterrent Module																																																										
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2015	Savana	Chassis	Electronic Brake Control Module																																																										
H	2015	Savana	Body	Body Control Module																																																										
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2015	Savana	Body	Rollover Sensor Module																																																								
H	2015	Savana	Body	Instrument Cluster																																																								
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																								
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																								
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																								
H	2015	Savana	Body	Auxiliary Heater Control Module																																																								
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																								
H	2015	Savana	Body	Parking Assist Control Module																																																								
H	2015	Savana	Body	Theft Deterrent Module																																																								
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
H	2016	Express	Chassis	Electronic Brake Control Module																																																								
H	2016	Express	Body	Body Control Module																																																								
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2016	Express	Body	Instrument Cluster																																																								
H	2016	Express	Body	Chime Alarm Control Module																																																								
H	2016	Express	Body	Base Radio																																																								
H	2016	Express	Body	Navigation Radio																																																								
H	2016	Express	Body	Uplevel Radio																																																								
H	2016	Express	Body	Digital Radio Receiver Control Module																																																								
H	2016	Express	Body	Telematics Communication Interface Control Module																																																								
H	2016	Express	Body	Auxiliary Heater Control Module																																																								
H	2016	Express	Body	Remote Control Door Lock Receiver																																																								
H	2016	Express	Body	Parking Assist Control Module																																																								
H	2016	Express	Body	Theft Deterrent Module																																																								
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
H	2016	Savana	Chassis	Electronic Brake Control Module																																																								
H	2016	Savana	Body	Body Control Module																																																								
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2016	Savana	Body	Instrument Cluster																																																								
H	2016	Savana	Body	Chime Alarm Control Module																																																								
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																								
H	2016	Savana	Body	Telematics Communication Interface Control Module																																																								
H	2016	Savana	Body	Auxiliary Heater Control Module																																																								
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																								
H	2016	Savana	Body	Parking Assist Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2016	Savana	Body	Theft Deterrent Module																																																								
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																								
J	2004	ALL	Chassis	Electronic Brake Control Module																																																								
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
J	2007	ALL	Chassis	Electronic Brake Control Module																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																								
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																								
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																																								
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																								
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Tracker	Chassis	Power Steering Control Module																																																								
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2013	Tracker	Body	Body Control Module																																																								
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2013	Tracker	Body	Passenger Presence Module																																																								
J	2013	Tracker	Body	Instrument Cluster																																																								
J	2013	Tracker	Body	Radio																																																								
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																																								
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																																								
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																																								
J	2013	Tracker	Body	Front Seat Heating Control Module																																																								
J	2013	Tracker	Body	Parking Assist Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2013	Tracker	Body	Frontview Camera Module																																																									
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2013	Trax	Chassis	Electronic Brake Control Module																																																										
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Trax	Chassis	Power Steering Control Module																																																										
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Trax	Body	Body Control Module																																																									
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Trax	Body	Passenger Presence Module																																																										
J	2013	Trax	Body	Instrument Cluster																																																									
J	2013	Trax	Body	Radio																																																									
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Trax	Body	Front Seat Heating Control Module																																																										
J	2013	Trax	Body	Parking Assist Control Module																																																										
J	2013	Trax	Body	Frontview Camera Module																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																									
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																									
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																									
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																									
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																									
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																									
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module						V																																																			
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																									
J	2014	Tracker	Chassis	Power Steering Control Module																																																									
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2014	Tracker	Body	Body Control Module																																																								
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2014	Tracker	Body	Passenger Presence Module																																																									
J	2014	Tracker	Body	Instrument Cluster																																																								
J	2014	Tracker	Body	Radio																																																								
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																																									
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																																									
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																																									
J	2014	Tracker	Body	Front Seat Heating Control Module																																																									
J	2014	Tracker	Body	Parking Assist Control Module																																																									
J	2014	Tracker	Body	Frontview Camera Module																																																									
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module						V																																																			
J	2014	Trax	Chassis	Electronic Brake Control Module																																																										
J	2014	Trax	Chassis	Power Steering Control Module																																																										
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Trax	Body	Body Control Module																																																									
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Trax	Body	Passenger Presence Module																																																										
J	2014	Trax	Body	Instrument Cluster																																																									
J	2014	Trax	Body	Radio																																																									
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Trax	Body	Front Seat Heating Control Module																																																										
J	2014	Trax	Body	Parking Assist Control Module																																																										
J	2014	Trax	Body	Frontview Camera Module																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																									
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																									
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																									
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																									
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																									
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																									
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																									
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																									
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																									
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module						V																																																			
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2015	Tracker	Chassis	Power Steering Control Module																																																									
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2015	Tracker	Body	Body Control Module																																																									
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2015	Tracker	Body	Instrument Cluster																																																									
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																																									
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																																									
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																																									
J	2015	Tracker	Body	Front Seat Heating Control Module																																																									
J	2015	Tracker	Body	Parking Assist Control Module																																																									
J	2015	Tracker	Body	Frontview Camera Module																																																									
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																									
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																									
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																									
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																									
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																									
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																									
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																									
J	2015	Trax	Powertrain	Chassis Control Module																																																									
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module						V																																																			
J	2015	Trax	Chassis	Electronic Brake Control Module																																																									
J	2015	Trax	Chassis	Power Steering Control Module																																																									
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2015	Trax	Body	Body Control Module																																																									
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2015	Trax	Body	Passenger Presence Module																																																									
J	2015	Trax	Body	Instrument Cluster																																																									
J	2015	Trax	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																									
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Trax	Body	Seat Memory Control Module																																																										
J	2015	Trax	Body	Front Seat Heating Control Module																																																										
J	2015	Trax	Body	Right Side Object Detection Control Module																																																										
J	2015	Trax	Body	Left Side Object Detection Control Module																																																										
J	2015	Trax	Body	Parking Assist Control Module																																																										
J	2015	Trax	Body	Frontview Camera Module																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																										
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2016	Tracker	Chassis	Power Steering Control Module																																																										
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Tracker	Body	Body Control Module																																																										
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Tracker	Body	Instrument Cluster																																																										
J	2016	Tracker	Body	Trailer Interface Control Module																																																										
J	2016	Tracker	Body	Radio																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Tracker	Body	Front Seat Heating Control Module																																																										
J	2016	Tracker	Body	Parking Assist Control Module																																																										
J	2016	Tracker	Body	Frontview Camera Module																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																												
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																												
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																												
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																												
J	2016	Trax	Powertrain	Chassis Control Module																																																												
J	2016	Trax	Chassis	Electronic Brake Control Module																																																												
J	2016	Trax	Chassis	Power Steering Control Module																																																												
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2016	Trax	Body	Body Control Module																																																												
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2016	Trax	Body	Passenger Presence Module																																																												
J	2016	Trax	Body	Instrument Cluster																																																												
J	2016	Trax	Body	Trailer Interface Control Module																																																												
J	2016	Trax	Body	Radio																																																												
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																												
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
J	2016	Trax	Body	Seat Memory Control Module																																																												
J	2016	Trax	Body	Front Seat Heating Control Module																																																												
J	2016	Trax	Body	Right Side Object Detection Control Module																																																												
J	2016	Trax	Body	Left Side Object Detection Control Module																																																												
J	2016	Trax	Body	Parking Assist Control Module																																																												
J	2016	Trax	Body	Frontview Camera Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM													V	V																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																V	V	V		V	V	V																																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																													
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																				
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																													
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																				
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																													
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																				
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																												

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																			
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module													V	V																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																V	V	V		V	V	V																																			
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																V	V	V		V	V	V																																			
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																											
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																			
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module													V	V																																											
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																				V	V	V	V	V																																	
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																											
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																				V	V	V	V	V																																	
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module													V	V																																											
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																V	V	V		V	V	V																																			
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																				V	V	V	V	V																																	
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																									
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
K	2004	ALL	Chassis	ESC																																																								
K	2004	ALL	Chassis	Rear Wheel Steering																																																									
K	2004	ALL	Chassis	Tire Pressure Monitor																																																									
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																									
K	2004	ALL	Chassis	VSES																																																								
K	2004	ALL	Body	Amplifier (Bose)																																																									
K	2004	ALL	Body	Body Control Module																																					V	V	V																		
K	2004	ALL	Body	CD Changer																																																									
K	2004	ALL	Body	Chime																																																									
K	2004	ALL	Body	Driver Door Module																																					V	V	V																		
K	2004	ALL	Body	Driver Seat Module																																																									
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2004	ALL	Body	Instrument Panel Cluster																																																										
K	2004	ALL	Body	OnStar																																																									
K	2004	ALL	Body	Passenger Door Module																																					V	V	V																		
K	2004	ALL	Body	Passenger Presence System																																																										
K	2004	ALL	Body	Radio Base																																																										
K	2004	ALL	Body	Radio Uplevel																																																										
K	2004	ALL	Body	Radio Navigation																																																										
K	2004	ALL	Body	Rear Aux. Climate Module																																					V																				
K	2004	ALL	Body	Rear HVAC																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2004	ALL	Body	Rear Seat Audio																																						V																		
K	2004	ALL	Body	Rear Seat Entertainment																																																							
K	2004	ALL	Body	Supplemental Inflatable Restraint																																						V	V																		
K	2004	ALL	Body	Vehicle Theft Deterrent																																						V																		
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM													V	V																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																V	V	V		V	V	V																																		
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																		
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																		
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																							
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																							
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																										
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																		
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																							
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module													V	V																																										
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																V	V	V		V	V	V																																		
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																							
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																		
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																							
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																		
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module													V	V																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																V	V	V		V	V	V																																		
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																V	V	V		V	V	V																																		
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																							
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																		
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																										
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																				V	V	V	V	V																																
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																							
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module													V	V																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																V	V	V		V	V	V																																		
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																				V	V	V	V	V																																
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																							
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																							
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																									
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
K	2005	ALL	Chassis	ESC																																																									
K	2005	ALL	Chassis	Rear Wheel Steering																																																									
K	2005	ALL	Chassis	Tire Pressure Monitor																																																									
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																									
K	2005	ALL	Chassis	VSES																																																									
K	2005	ALL	Body	Amplifier (Bose)																																																									
K	2005	ALL	Body	Body Control Module																																					V	V	V																			
K	2005	ALL	Body	CD Changer																																																									
K	2005	ALL	Body	Chime																																																									
K	2005	ALL	Body	Disc Player and Video Display																																																									
K	2005	ALL	Body	Driver Door Module																																					V	V	V																			
K	2005	ALL	Body	Driver Seat Module																																																									
K	2005	ALL	Body	Generator Battery Control Module																																																									
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																									
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2005	ALL	Body	Instrument Panel Cluster																																																									
K	2005	ALL	Body	Passenger Door Module																																					V	V	V																			
K	2005	ALL	Body	Passenger Presence System																																																									
K	2005	ALL	Body	Base Radio																																																									
K	2005	ALL	Body	Uplevel Radio																																																									
K	2005	ALL	Body	Navigation Radio																																																									
K	2005	ALL	Body	Rear Aux. Climate Module																																					V																					
K	2005	ALL	Body	Rear HVAC																																																									
K	2005	ALL	Body	Rear Seat Audio																																					V																					
K	2005	ALL	Body	Supplemental Inflatable Restraint																																					V																					V
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2005	ALL	Body	Vehicle Theft Deterrent																																					V																					
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM													V	V																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																V	V	V		V	V	V																																			

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																				V	V	V	V	V																																		
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																				V	V	V	V	V																																		
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																				V	V	V	V	V																																		
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																									
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
K	2006	ALL	Chassis	ESC																																																								
K	2006	ALL	Chassis	Tire Pressure Monitor																																																									
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																									
K	2006	ALL	Chassis	VSES																																																								
K	2006	ALL	Body	Amplifier (Bose)																																																									
K	2006	ALL	Body	Body Control Module																																					V	V	V																		
K	2006	ALL	Body	CD Changer																																																									
K	2006	ALL	Body	Chime																																																									
K	2006	ALL	Body	Disc Player and Video Display																																																									
K	2006	ALL	Body	Driver Door Module																																					V	V	V																		
K	2006	ALL	Body	Driver Seat Module																																																									
K	2006	ALL	Body	Generator Battery Control Module																																																									
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																							
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																								
K	2006	ALL	Body	Instrument Panel Cluster																																																							
K	2006	ALL	Body	Passenger Door Module																																					V	V	V																
K	2006	ALL	Body	Passenger Presence System																																																							
K	2006	ALL	Body	Base Radio																																																							
K	2006	ALL	Body	Uplevel Radio																																																							
K	2006	ALL	Body	Navigation Radio																																																							
K	2006	ALL	Body	Rear Aux. Climate Module																																					V																		
K	2006	ALL	Body	Rear HVAC																																																							
K	2006	ALL	Body	Rear Seat Audio																																					V																		
K	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
K	2006	ALL	Body	Vehicle Theft Deterrent																																					V																		
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																						
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																										V		V	V																										
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																							
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																							
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																										V		V	V																										
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																							
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																							
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																										V		V	V																										
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																							
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																							
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																										V		V	V																										
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																							
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																							
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																							
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																							
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																							
K	2007	Avalanche	Chassis	Electronic Suspension Control																																																							
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																																							
K	2007	Avalanche	Body	Amplifier (Bose)																																																							
K	2007	Avalanche	Body	Assist Step Controller																																																							
K	2007	Avalanche	Body	Body Control Module			V																																			V	V																
K	2007	Avalanche	Body	Body Control Module (aux.)																																																							
K	2007	Avalanche	Body	Digital Radio Receiver																																																							
K	2007	Avalanche	Body	Driver Door Switch																																					V	V	V																
K	2007	Avalanche	Body	HVAC Control Module Auto																																						V		V															
K	2007	Avalanche	Body	HVAC Control Module Manual																																						V		V															
K	2007	Avalanche	Body	Instrument Panel Cluster																																																						
K	2007	Avalanche	Body	Memory Seat Module																																																						
K	2007	Avalanche	Body	Park Assist Module																																																						
K	2007	Avalanche	Body	Passenger Door Switch																																					V	V	V																
K	2007	Avalanche	Body	Passenger Presence System																																					V																	
K	2007	Avalanche	Body	Radio																																																						
K	2007	Avalanche	Body	Rear Heated Seat Module																																																						
K	2007	Avalanche	Body	Rear HVAC/RSA																																																						
K	2007	Avalanche	Body	Rollover Sensor																																																						
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																																					V																	
K	2007	Avalanche	Body	Theft Deterrent Module																																																						
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																										V		V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																							
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																							
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																							
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																							
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																							
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																										
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																							
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																		
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																										
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																							
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																							
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																							
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																							
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																							
K	2007	Suburban	Chassis	Electronic Suspension Control																																																							
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																							
K	2007	Suburban	Body	Amplifier (Bose)																																																							
K	2007	Suburban	Body	Assist Step Controller																																																							
K	2007	Suburban	Body	Body Control Module			V																																			V	V																	
K	2007	Suburban	Body	Body Control Module (aux.)																																																							
K	2007	Suburban	Body	Digital Radio Receiver																																																							
K	2007	Suburban	Body	Driver Door Switch																																					V	V	V																	
K	2007	Suburban	Body	HVAC Control Module Auto																																						V		V																
K	2007	Suburban	Body	HVAC Control Module Manual																																						V		V																
K	2007	Suburban	Body	Instrument Panel Cluster																																																							
K	2007	Suburban	Body	Lift Gate Module																																					V																		
K	2007	Suburban	Body	Memory Seat Module																																																							
K	2007	Suburban	Body	Park Assist Module																																																							
K	2007	Suburban	Body	Passenger Door Switch																																					V	V	V																	
K	2007	Suburban	Body	Passenger Presence System																																					V																		
K	2007	Suburban	Body	Radio																																																							
K	2007	Suburban	Body	Rear Heated Seat Module																																																							
K	2007	Suburban	Body	Rear HVAC/RSA																																																							
K	2007	Suburban	Body	Rollover Sensor																																																							
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																					V																		
K	2007	Suburban	Body	Theft Deterrent Module																																																							
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																							
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V													V																							
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																										
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																							
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																							
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																							
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																							
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																							
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																							
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																									
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																							
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																						
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																							
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																						
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																						
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																							
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																									
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																						
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																					
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																									
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																						
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																						
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																							
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																									
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																						
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																						
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																						
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																															
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																						
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																						
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																						
K	2007	Silverado	Chassis	Electronic Suspension Control																																																						
K	2007	Silverado	Chassis	Trailer Brake Control Module																																																						
K	2007	Silverado	Body	Amplifier (Bose)																																																						
K	2007	Silverado	Body	Body Control Module			V																																				V	V															
K	2007	Silverado	Body	Body Control Module (aux.)																																																						
K	2007	Silverado	Body	Digital Radio Receiver																																																						
K	2007	Silverado	Body	Driver Door Switch																																						V	V	V															
K	2007	Silverado	Body	HVAC Control Module Auto																																								V		V														
K	2007	Silverado	Body	HVAC Control Module Manual																																								V		V														
K	2007	Silverado	Body	Instrument Panel Cluster																																																						
K	2007	Silverado	Body	Memory Seat Module																																																						
K	2007	Silverado	Body	Park Assist Module																																																						
K	2007	Silverado	Body	Passenger Door Switch																																						V	V	V															
K	2007	Silverado	Body	Passenger Presence System																																						V																	
K	2007	Silverado	Body	Radio																																																						
K	2007	Silverado	Body	Rear Heated Seat Module																																																						
K	2007	Silverado	Body	Rear HVAC/RSA																																																						
K	2007	Silverado	Body	Rollover Sensor																																																						
K	2007	Silverado	Body	Supplemental Inflatable Restraint																																						V																	
K	2007	Silverado	Body	Theft Deterrent Module																																																						
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																									
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																						
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																							
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																									
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																						
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																							
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																								
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																									
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																									
K	2007	Tahoe	Body	Amplifier (Bose)																																																									
K	2007	Tahoe	Body	Assist Step Controller																																																									
K	2007	Tahoe	Body	Body Control Module			V																																			V	V																		
K	2007	Tahoe	Body	Body Control Module (aux.)																																																									
K	2007	Tahoe	Body	Digital Radio Receiver																																																									
K	2007	Tahoe	Body	Driver Door Switch																																					V	V	V																		
K	2007	Tahoe	Body	HVAC Control Module Auto																																						V		V																	
K	2007	Tahoe	Body	HVAC Control Module Manual																																						V		V																	
K	2007	Tahoe	Body	Instrument Panel Cluster																																																									
K	2007	Tahoe	Body	Lift Gate Module																																					V																				
K	2007	Tahoe	Body	Memory Seat Module																																																									
K	2007	Tahoe	Body	Park Assist Module																																																									
K	2007	Tahoe	Body	Passenger Door Switch																																					V	V	V																		
K	2007	Tahoe	Body	Passenger Presence System																																					V																				
K	2007	Tahoe	Body	Radio																																																									
K	2007	Tahoe	Body	Rear Heated Seat Module																																																									
K	2007	Tahoe	Body	Rear HVAC/RSA																																																									
K	2007	Tahoe	Body	Rollover Sensor																																																									
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																					V																				
K	2007	Tahoe	Body	Theft Deterrent Module																																																									
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																								
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																								
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																								
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																								
K	2008	Avalanche	Chassis	Electronic Brake Control Module																																			V																						
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																									
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																									
K	2008	Avalanche	Body	Amplifier (Bose)																																																									
K	2008	Avalanche	Body	Assist Step Controller																																																									
K	2008	Avalanche	Body	Body Control Module			V																																			V	V																		
K	2008	Avalanche	Body	Body Control Module (aux.)																																																									
K	2008	Avalanche	Body	Digital Radio Receiver																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2008	Avalanche	Body	Driver Door Switch																																					V	V	V																	
K	2008	Avalanche	Body	HVAC Control Module Auto																																						V		V																
K	2008	Avalanche	Body	HVAC Control Module Manual																																						V		V																
K	2008	Avalanche	Body	Instrument Panel Cluster																																																							
K	2008	Avalanche	Body	Memory Seat Module																																																							
K	2008	Avalanche	Body	Park Assist Module																																																						
K	2008	Avalanche	Body	Passenger Door Switch																																					V	V	V																	
K	2008	Avalanche	Body	Passenger Presence System																																					V																		
K	2008	Avalanche	Body	Radio																																																						
K	2008	Avalanche	Body	Rear Heated Seat Module																																																						
K	2008	Avalanche	Body	Rear HVAC/RSA																																																						
K	2008	Avalanche	Body	Rollover Sensor																																																						
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																					V																		
K	2008	Avalanche	Body	Theft Deterrent Module																																																						
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																										V		V	V																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																						
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V												V																							
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																										V		V	V																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																						
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																						
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V												V																							
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																										V		V	V																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																						
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																						
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V												V																							
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																										V		V	V																										
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																						
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																V	V																						
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																										V		V	V																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																						
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																						
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V												V																							
K	2008	Suburban	Chassis	EBCM Under 8600 GVW																																			V																				
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																						
K	2008	Suburban	Chassis	Electronic Suspension Control																																																						
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																						
K	2008	Suburban	Body	Amplifier (Bose)																																																						
K	2008	Suburban	Body	Assist Step Controller																																																						
K	2008	Suburban	Body	Body Control Module			V																																			V	V																
K	2008	Suburban	Body	Body Control Module (aux.)																																																						
K	2008	Suburban	Body	Digital Radio Receiver																																																						
K	2008	Suburban	Body	Driver Door Switch																																					V	V	V																	
K	2008	Suburban	Body	HVAC Control Module Auto																																						V		V																
K	2008	Suburban	Body	HVAC Control Module Manual																																						V		V																
K	2008	Suburban	Body	Instrument Panel Cluster																																																						
K	2008	Suburban	Body	Lift Gate Module																																					V																		
K	2008	Suburban	Body	Memory Seat Module																																																						
K	2008	Suburban	Body	Park Assist Module																																																						
K	2008	Suburban	Body	Passenger Door Switch																																					V	V	V																	
K	2008	Suburban	Body	Passenger Presence System																																					V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2008	Suburban	Body	Radio																																																										
K	2008	Suburban	Body	Rear Heated Seat Module																																																										
K	2008	Suburban	Body	Rear HVAC/RSA																																																										
K	2008	Suburban	Body	Rollover Sensor																																																										
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																					V																					
K	2008	Suburban	Body	Theft Deterrent Module																																																										
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																													
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V													V																									
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																												
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																									
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																									
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																												
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																									
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																									
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																									
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																												
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																									
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																		
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																			V																							
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Silverado	Chassis	Electronic Suspension Control																																																										
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																										
K	2008	Silverado	Body	Amplifier (Bose)																																																										
K	2008	Silverado	Body	Body Control Module			V																																			V	V																			
K	2008	Silverado	Body	Body Control Module (aux.)																																																										
K	2008	Silverado	Body	Digital Radio Receiver																																																										
K	2008	Silverado	Body	Driver Door Switch																																					V	V	V																			
K	2008	Silverado	Body	HVAC Control Module Auto																																							V		V																	
K	2008	Silverado	Body	HVAC Control Module Manual																																							V		V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2008	Silverado	Body	Instrument Panel Cluster																																																									
K	2008	Silverado	Body	Memory Seat Module																																																									
K	2008	Silverado	Body	Park Assist Module																																																									
K	2008	Silverado	Body	Passenger Door Switch																																					V	V	V																		
K	2008	Silverado	Body	Passenger Presence System																																					V																				
K	2008	Silverado	Body	Radio																																																									
K	2008	Silverado	Body	Rear Heated Seat Module																																																										
K	2008	Silverado	Body	Rear HVAC/RSA																																																										
K	2008	Silverado	Body	Rollover Sensor																																																										
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																					V																				
K	2008	Silverado	Body	Theft Deterrent Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																													
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																									
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																													
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																									
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																													
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																									
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Tahoe	Chassis	Electronic Brake Control Module																																			V																						
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2008	Tahoe	Body	Amplifier (Bose)																																																										
K	2008	Tahoe	Body	Assist Step Controller																																																										
K	2008	Tahoe	Body	Body Control Module			V																																			V	V																		
K	2008	Tahoe	Body	Body Control Module (aux.)																																																										
K	2008	Tahoe	Body	Digital Radio Receiver																																																										
K	2008	Tahoe	Body	Driver Door Switch																																					V	V	V																		
K	2008	Tahoe	Body	HVAC Control Module Auto																																						V		V																		
K	2008	Tahoe	Body	HVAC Control Module Manual																																						V		V																		
K	2008	Tahoe	Body	Instrument Panel Cluster																																																										
K	2008	Tahoe	Body	Lift Gate Module																																					V																					
K	2008	Tahoe	Body	Memory Seat Module																																																										
K	2008	Tahoe	Body	Park Assist Module																																																										
K	2008	Tahoe	Body	Passenger Door Switch																																					V	V	V																		
K	2008	Tahoe	Body	Passenger Presence System																																					V																				
K	2008	Tahoe	Body	Radio																																																									
K	2008	Tahoe	Body	Rear Heated Seat Module																																																										
K	2008	Tahoe	Body	Rear HVAC/RSA																																																										
K	2008	Tahoe	Body	Rollover Sensor																																																										
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																					V																				
K	2008	Tahoe	Body	Theft Deterrent Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																													
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																								
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																					V																			
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																					V	V	V																	
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
K	2008	Tahoe Hybrid	Body	Body Control Module			V																																			V	V																	
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																					V	V	V																	
K	2008	Tahoe Hybrid	Body	HVAC Control Module																																						V		V																
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																					V																			
K	2008	Tahoe Hybrid	Body	Memory Seat Module																																																								
K	2008	Tahoe Hybrid	Body	Park Assist Module																																																								
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																					V	V	V																	
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																					V																			
K	2008	Tahoe Hybrid	Body	Radio																																																								
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																								
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																					V																			
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																	V	V																						
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																	V	V																						
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																	V	V																						
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																	V	V																						
K	2009	Avalanche	Chassis	Electronic Brake Control Module																																			V																					
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																								
K	2009	Avalanche	Body	Amplifier (Bose)																																																								
K	2009	Avalanche	Body	Assist Step Controller																																																								
K	2009	Avalanche	Body	Body Control Module			V																																			V	V																	
K	2009	Avalanche	Body	Body Control Module (aux.)																																																								
K	2009	Avalanche	Body	Digital Radio Receiver																																																								
K	2009	Avalanche	Body	Driver Door Switch																																					V	V	V																	
K	2009	Avalanche	Body	HVAC Control Module Auto																																						V		V																
K	2009	Avalanche	Body	HVAC Control Module Manual																																						V		V																
K	2009	Avalanche	Body	Instrument Panel Cluster																																																								
K	2009	Avalanche	Body	Memory Seat Module																																																								
K	2009	Avalanche	Body	Park Assist Module																																																								
K	2009	Avalanche	Body	Passenger Door Switch																																					V	V	V																	
K	2009	Avalanche	Body	Passenger Presence System																																					V																			
K	2009	Avalanche	Body	Radio																																																								
K	2009	Avalanche	Body	Rear Heated Seat Module																																																								
K	2009	Avalanche	Body	Rear HVAC/RSA																																																								
K	2009	Avalanche	Body	Rollover Sensor																																																								
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																					V																			
K	2009	Avalanche	Body	Theft Deterrent Module																																																								
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V	V	V										V																									
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V	V	V										V																									
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																			V																			
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																								
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																								
K	2009	Cheyenne	Body	Amplifier (Bose)																																																								
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																								
K	2009	Cheyenne	Body	Digital Radio Receiver																																																								
K	2009	Cheyenne	Body	Driver Door Switch																																					V	V	V																	
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																								
K	2009	Cheyenne	Body	Park Assist Module																																																								
K	2009	Cheyenne	Body	Passenger Door Switch																																					V	V	V																	
K	2009	Cheyenne	Body	Passenger Presence System																																					V																			
K	2009	Cheyenne	Body	Rear Heated Seat Module																																																								
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																								
K	2009	Cheyenne	Body	Rollover Sensor																																																								
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																					V																			
K	2009	Cheyenne	Body	Theft Deterrent Module																																																								
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																						
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																										V		V	V																										
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																						
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																V	V																						
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																										V		V	V																										
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																						
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																						
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																V	V																						
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																										V		V	V																										
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																						
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																V	V																						
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																										V		V	V																										
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																						
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																						
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																V	V																						
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																										V		V	V																										
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																						
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																V	V																						
K	2009	Suburban	Chassis	EBCM Under 8600 GVW																																			V																				
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																						
K	2009	Suburban	Chassis	Electronic Suspension Control																																																						
K	2009	Suburban	Chassis	Trailer Brake Control Module																																																						
K	2009	Suburban	Body	Amplifier (Bose)																																																						
K	2009	Suburban	Body	Assist Step Controller																																																						
K	2009	Suburban	Body	Body Control Module			V																																			V	V																
K	2009	Suburban	Body	Body Control Module (aux.)																																																						
K	2009	Suburban	Body	Digital Radio Receiver																																																						
K	2009	Suburban	Body	Driver Door Switch																																					V	V	V																
K	2009	Suburban	Body	HVAC Control Module Auto																																						V		V															
K	2009	Suburban	Body	HVAC Control Module Manual																																						V		V															
K	2009	Suburban	Body	Instrument Panel Cluster																																																						
K	2009	Suburban	Body	Left Side Object Detection Module																																																						
K	2009	Suburban	Body	Lift Gate Module																																					V																		
K	2009	Suburban	Body	Memory Seat Module																																																						
K	2009	Suburban	Body	Park Assist Module																																																						
K	2009	Suburban	Body	Passenger Door Switch																																					V	V	V																
K	2009	Suburban	Body	Passenger Presence System																																					V																		
K	2009	Suburban	Body	Radio																																																						
K	2009	Suburban	Body	Rear Heated Seat Module																																																						
K	2009	Suburban	Body	Rear HVAC/RSA																																																						
K	2009	Suburban	Body	Right Side Object Detection Module																																																						
K	2009	Suburban	Body	Rollover Sensor																																																						
K	2009	Suburban	Body	Supplemental Inflatable Restraint																																					V																		
K	2009	Suburban	Body	Theft Deterrent Module																																																						
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																										V		V																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																						
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V										V																							
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																										V		V	V																										
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																						
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																						
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V										V																							
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																										V		V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																	V	V																						
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																												V		V	V																									
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																												V		V	V																									
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																	V	V																						
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																												V		V	V																									
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																	V	V																						
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																												V		V	V																									
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																	V	V																						
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																												V		V	V																									
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																												V		V	V																									
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																						
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																												V		V	V																									
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																												V			V																									
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																			V																					
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																								
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
K	2009	Silverado	Chassis	Electronic Suspension Control																																																								
K	2009	Silverado	Chassis	Trailer Brake Control Module																																																								
K	2009	Silverado	Body	Amplifier (Bose)																																																								
K	2009	Silverado	Body	Body Control Module			V																																			V	V																	
K	2009	Silverado	Body	Body Control Module (aux.)																																																								
K	2009	Silverado	Body	Digital Radio Receiver																																																								
K	2009	Silverado	Body	Driver Door Switch																																					V	V	V																	
K	2009	Silverado	Body	HVAC Control Module Auto																																						V		V																
K	2009	Silverado	Body	HVAC Control Module Manual																																						V		V																
K	2009	Silverado	Body	Instrument Panel Cluster																																																								
K	2009	Silverado	Body	Memory Seat Module																																																								
K	2009	Silverado	Body	Park Assist Module																																																								
K	2009	Silverado	Body	Passenger Door Switch																																					V	V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2009	Silverado	Body	Passenger Presence System																																					V																		
K	2009	Silverado	Body	Radio																																																						
K	2009	Silverado	Body	Rear Heated Seat Module																																																						
K	2009	Silverado	Body	Rear HVAC/RSA																																																						
K	2009	Silverado	Body	Rollover Sensor																																																						
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																					V																		
K	2009	Silverado	Body	Theft Deterrent Module																																																						
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V		V																											
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																						
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																						
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																						
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																						
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																						
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																						
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																						
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																						
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																						
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																						
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																						
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																						
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																						
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																						
K	2009	Silverado Hybrid	Body	Body Control Module			V																																			V	V																	
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																						
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																						
K	2009	Silverado Hybrid	Body	Driver Door Switch																																					V	V	V																	
K	2009	Silverado Hybrid	Body	HVAC Control Module																																						V		V																
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																						
K	2009	Silverado Hybrid	Body	Memory Seat Module																																																						
K	2009	Silverado Hybrid	Body	Park Assist Module																																																						
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																					V	V	V																	
K	2009	Silverado Hybrid	Body	Passenger Presence System																																					V																		
K	2009	Silverado Hybrid	Body	Radio																																																						
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																						
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																						
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																						
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																						
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																					V																		
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																						
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																						
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																						
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V											V																						
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																						
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																V	V	V		V	V	V											V																						
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																	V	V																				
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																						
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																	V	V																						
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
K	2009	Tahoe	Chassis	Electronic Brake Control Module																																			V																					
K	2009	Tahoe	Chassis	Electronic Suspension Control																																																								
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																																								
K	2009	Tahoe	Body	Amplifier (Bose)																																																								
K	2009	Tahoe	Body	Assist Step Controller																																																								
K	2009	Tahoe	Body	Body Control Module			V																																			V	V																	
K	2009	Tahoe	Body	Body Control Module (aux.)																																																								
K	2009	Tahoe	Body	Digital Radio Receiver																																																								
K	2009	Tahoe	Body	Driver Door Switch																																					V	V	V																	
K	2009	Tahoe	Body	HVAC Control Module Auto																																						V		V																
K	2009	Tahoe	Body	HVAC Control Module Manual																																						V		V																
K	2009	Tahoe	Body	Instrument Panel Cluster																																																								
K	2009	Tahoe	Body	Left Side Object Detection Module																																																								
K	2009	Tahoe	Body	Lift Gate Module																																					V																			
K	2009	Tahoe	Body	Memory Seat Module																																																								
K	2009	Tahoe	Body	Park Assist Module																																																								
K	2009	Tahoe	Body	Passenger Door Switch																																					V	V	V																	
K	2009	Tahoe	Body	Passenger Presence System																																					V																			
K	2009	Tahoe	Body	Radio																																																								
K	2009	Tahoe	Body	Rear Heated Seat Module																																																								
K	2009	Tahoe	Body	Rear HVAC/RSA																																																								
K	2009	Tahoe	Body	Right Side Object Detection Module																																																								
K	2009	Tahoe	Body	Rollover Sensor																																																								
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																																					V																			
K	2009	Tahoe	Body	Theft Deterrent Module																																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																											
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																								
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
K	2009	Tahoe Hybrid	Body	Body Control Module			V																																			V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																					V	V	V																			
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																																									
K	2009	Tahoe Hybrid	Body	HVAC Control Module																																						V		V																		
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2009	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																					V	V	V																		
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																					V																				
K	2009	Tahoe Hybrid	Body	Radio																																																									
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																										
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																					V																				
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																													
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																								
K	2010	Avalanche	Chassis	Electronic Brake Control Module																																			V																						
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Avalanche	Body	Amplifier (Bose)																																																										
K	2010	Avalanche	Body	Assist Step Controller																																																										
K	2010	Avalanche	Body	Body Control Module			V																																			V	V																		
K	2010	Avalanche	Body	Body Control Module (aux.)																																																										
K	2010	Avalanche	Body	Digital Radio Receiver																																																										
K	2010	Avalanche	Body	Driver Door Switch																																					V	V	V																		
K	2010	Avalanche	Body	HVAC Control Module Auto																																						V		V																		
K	2010	Avalanche	Body	HVAC Control Module Manual																																						V		V																		
K	2010	Avalanche	Body	Instrument Panel Cluster																																																										
K	2010	Avalanche	Body	Memory Seat Module																																																										
K	2010	Avalanche	Body	Park Assist Module																																																										
K	2010	Avalanche	Body	Passenger Door Switch																																					V	V	V																		
K	2010	Avalanche	Body	Passenger Presence System																																					V																				
K	2010	Avalanche	Body	Radio																																																									
K	2010	Avalanche	Body	Rear Heated Seat Module																																																										
K	2010	Avalanche	Body	Rear HVAC/RSA																																																										
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2010	Avalanche	Body	Theft Deterrent Module																																																										
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																												
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																			V																						
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																									
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																									
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Cheyenne	Body	Amplifier (Bose)																																																									
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																									
K	2010	Cheyenne	Body	Digital Radio Receiver																																																									
K	2010	Cheyenne	Body	Driver Door Switch																																					V	V	V																			
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																									
K	2010	Cheyenne	Body	Park Assist Module																																																									
K	2010	Cheyenne	Body	Passenger Door Switch																																					V	V	V																			
K	2010	Cheyenne	Body	Passenger Presence System																																					V																			
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																									
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																									
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																									
K	2010	Cheyenne	Body	Theft Deterrent Module																																																									
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																														V																												
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																									
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																									
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																														V																												
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																									
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																									
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																								
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																												
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																								
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																												
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																									
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																									
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																								
K	2010	Suburban	Chassis	EBCM Under 8600 GVW																																			V																						
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2010	Suburban	Chassis	Electronic Suspension Control																																																									
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Suburban	Body	Amplifier (Bose)																																																									
K	2010	Suburban	Body	Assist Step Controller																																																									
K	2010	Suburban	Body	Body Control Module			V																																			V	V																		
K	2010	Suburban	Body	Body Control Module (aux.)																																																									
K	2010	Suburban	Body	Digital Radio Receiver																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2010	Suburban	Body	Driver Door Switch																																					V	V	V																	
K	2010	Suburban	Body	HVAC Control Module Auto																																						V		V																
K	2010	Suburban	Body	HVAC Control Module Manual																																						V		V																
K	2010	Suburban	Body	Instrument Panel Cluster																																																							
K	2010	Suburban	Body	Left Side Object Detection Module																																																							
K	2010	Suburban	Body	Lift Gate Module																																					V																			
K	2010	Suburban	Body	Memory Seat Module																																																							
K	2010	Suburban	Body	Park Assist Module																																																							
K	2010	Suburban	Body	Passenger Door Switch																																					V	V	V																	
K	2010	Suburban	Body	Passenger Presence System																																					V																			
K	2010	Suburban	Body	Radio																																																							
K	2010	Suburban	Body	Rear Heated Seat Module																																																							
K	2010	Suburban	Body	Rear HVAC/RSA																																																							
K	2010	Suburban	Body	Right Side Object Detection Module																																																							
K	2010	Suburban	Body	Supplemental Inflatable Restraint																																																							
K	2010	Suburban	Body	Theft Deterrent Module																																																							
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																											V		V	V																										
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																											V		V	V																										
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																							
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																							
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																							
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																							
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																							
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																							
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																							
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																							
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																											V		V	V																										
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																											V		V	V																										
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																							
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																						
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																							
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																							
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																							
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																							
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																							
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																			V																					
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																							
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
K	2010	Silverado	Chassis	Electronic Suspension Control																																																										
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2010	Silverado	Body	Amplifier (Bose)																																																										
K	2010	Silverado	Body	Body Control Module			V																																			V	V																		
K	2010	Silverado	Body	Body Control Module (aux.)																																																										
K	2010	Silverado	Body	Digital Radio Receiver																																																										
K	2010	Silverado	Body	Driver Door Switch																																					V	V	V																			
K	2010	Silverado	Body	HVAC Control Module Auto																																						V		V																		
K	2010	Silverado	Body	HVAC Control Module Manual																																						V		V																		
K	2010	Silverado	Body	Instrument Panel Cluster																																																										
K	2010	Silverado	Body	Memory Seat Module																																																										
K	2010	Silverado	Body	Park Assist Module																																																										
K	2010	Silverado	Body	Passenger Door Switch																																					V	V	V																			
K	2010	Silverado	Body	Passenger Presence System																																					V																					
K	2010	Silverado	Body	Radio																																																										
K	2010	Silverado	Body	Rear Heated Seat Module																																																										
K	2010	Silverado	Body	Rear HVAC/RSA																																																										
K	2010	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2010	Silverado	Body	Theft Deterrent Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Silverado Hybrid	Body	Body Control Module			V																																			V	V																		
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Silverado Hybrid	Body	Driver Door Switch																																					V	V	V																			
K	2010	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2010	Silverado Hybrid	Body	HVAC Control Module																																						V		V																		
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Silverado Hybrid	Body	Park Assist Module																																																										
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																					V	V	V																			
K	2010	Silverado Hybrid	Body	Passenger Presence System																																					V																					
K	2010	Silverado Hybrid	Body	Radio																																																										
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																							
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																							
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																							
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																							
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																							
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																V	V																							
K	2010	Tahoe	Chassis	Electronic Brake Control Module																																			V																					
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																								
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Tahoe	Body	Amplifier (Bose)																																																								
K	2010	Tahoe	Body	Assist Step Controller																																																								
K	2010	Tahoe	Body	Body Control Module			V																																			V	V																	
K	2010	Tahoe	Body	Body Control Module (aux.)																																																								
K	2010	Tahoe	Body	Digital Radio Receiver																																																								
K	2010	Tahoe	Body	Driver Door Switch																																					V	V	V																	
K	2010	Tahoe	Body	HVAC Control Module Auto																																						V		V																
K	2010	Tahoe	Body	HVAC Control Module Manual																																						V		V																
K	2010	Tahoe	Body	Instrument Panel Cluster																																																								
K	2010	Tahoe	Body	Left Side Object Detection Module																																																								
K	2010	Tahoe	Body	Lift Gate Module																																					V																			
K	2010	Tahoe	Body	Memory Seat Module																																																								
K	2010	Tahoe	Body	Park Assist Module																																																								
K	2010	Tahoe	Body	Passenger Door Switch																																					V	V	V																	
K	2010	Tahoe	Body	Passenger Presence System																																					V																			
K	2010	Tahoe	Body	Radio																																																								
K	2010	Tahoe	Body	Rear Heated Seat Module																																																								
K	2010	Tahoe	Body	Rear HVAC/RSA																																																								
K	2010	Tahoe	Body	Right Side Object Detection Module																																																								
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																								
K	2010	Tahoe	Body	Theft Deterrent Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																											
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
K	2010	Tahoe Hybrid	Body	Body Control Module			V																																			V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																				V	V	V																			
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																																								
K	2010	Tahoe Hybrid	Body	HVAC Control Module																																					V		V																		
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																				V																				
K	2010	Tahoe Hybrid	Body	Park Assist Module																																																								
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																				V	V	V																		
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																				V																				
K	2010	Tahoe Hybrid	Body	Radio																																																								
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																											
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																V	V																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module																											V		V	V																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module																											V		V	V																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2011	Avalanche	Chassis	Electronic Brake Control Module																																			V																					
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																								
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
K	2011	Avalanche	Body	Amplifier (Bose)																																																								
K	2011	Avalanche	Body	Assist Step Controller																																																								
K	2011	Avalanche	Body	Body Control Module			V																																		V	V																		
K	2011	Avalanche	Body	Body Control Module (aux.)																																																								
K	2011	Avalanche	Body	Digital Radio Receiver																																																								
K	2011	Avalanche	Body	Driver Door Switch																																				V	V	V																		
K	2011	Avalanche	Body	HVAC Control Module Auto																																						V		V																
K	2011	Avalanche	Body	HVAC Control Module Manual																																						V		V																
K	2011	Avalanche	Body	Instrument Panel Cluster																																																								
K	2011	Avalanche	Body	Memory Seat Module																																																								
K	2011	Avalanche	Body	Park Assist Module																																																								
K	2011	Avalanche	Body	Passenger Door Switch																																				V	V	V																		
K	2011	Avalanche	Body	Passenger Presence System																																				V																				
K	2011	Avalanche	Body	Radio																																																								
K	2011	Avalanche	Body	Rear Heated Seat Module																																																								
K	2011	Avalanche	Body	Rear HVAC/RSA																																																								
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																								
K	2011	Avalanche	Body	Theft Deterrent Module																																																								
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																										V		V	V																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																V	V																							
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																			V																					
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																								
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																								
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																								
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																								
K	2011	Cheyenne	Body	Amplifier (Bose)																																																								
K	2011	Cheyenne	Body	Body Control Module			V																																			V	V																		
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																								
K	2011	Cheyenne	Body	Digital Radio Receiver																																																								
K	2011	Cheyenne	Body	Driver Door Switch																																					V	V	V																		
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																								
K	2011	Cheyenne	Body	Park Assist Module																																																								
K	2011	Cheyenne	Body	Passenger Door Switch																																					V	V	V																		
K	2011	Cheyenne	Body	Passenger Presence System																																					V																				
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																								
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																								
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																								
K	2011	Cheyenne	Body	Theft Deterrent Module																																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																													V																												
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																													V																												
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																V	V																							
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																										V		V	V																											
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																							
K	2011	Suburban	Chassis	EBCM Under 8600 GVW																																			V																					
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2011	Suburban	Chassis	Electronic Suspension Control																																																								
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																								
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																								
K	2011	Suburban	Body	Amplifier (Bose)																																																								
K	2011	Suburban	Body	Assist Step Controller																																																								
K	2011	Suburban	Body	Body Control Module			V																																			V	V																		
K	2011	Suburban	Body	Body Control Module (aux.)																																																								
K	2011	Suburban	Body	Digital Radio Receiver																																																								
K	2011	Suburban	Body	Driver Door Switch																																					V	V	V																		
K	2011	Suburban	Body	HVAC Control Module Auto																																							V		V																
K	2011	Suburban	Body	HVAC Control Module Manual																																							V		V																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2011	Suburban	Body	Instrument Panel Cluster																																																									
K	2011	Suburban	Body	Left Side Object Detection Module																																																										
K	2011	Suburban	Body	Lift Gate Module																																					V																					
K	2011	Suburban	Body	Memory Seat Module																																																									
K	2011	Suburban	Body	Park Assist Module																																																									
K	2011	Suburban	Body	Passenger Door Switch																																					V	V	V																			
K	2011	Suburban	Body	Passenger Presence System																																					V																					
K	2011	Suburban	Body	Radio																																																									
K	2011	Suburban	Body	Rear Heated Seat Module																																																										
K	2011	Suburban	Body	Rear HVAC/RSA																																																										
K	2011	Suburban	Body	Right Side Object Detection Module																																																										
K	2011	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2011	Suburban	Body	Theft Deterrent Module																																																										
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																											V		V	V																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																											V		V	V																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																								
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module																											V		V	V																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module																											V		V	V																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																								
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																											V		V	V																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																											V		V	V																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																								
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																											V			V																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																				V	V	V	V	V																																	
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																				V	V	V	V	V																																	
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																			V																						
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
K	2011	Silverado	Chassis	Electronic Suspension Control																																																										
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2011	Silverado	Body	Amplifier (Bose)																																																										
K	2011	Silverado	Body	Body Control Module			V																																			V	V																		
K	2011	Silverado	Body	Body Control Module (aux.)																																																										
K	2011	Silverado	Body	Digital Radio Receiver																																																										
K	2011	Silverado	Body	Driver Door Switch																																					V	V	V																			
K	2011	Silverado	Body	HVAC Control Module Auto																																						V		V																		
K	2011	Silverado	Body	HVAC Control Module Manual																																						V		V																		
K	2011	Silverado	Body	Instrument Panel Cluster																																																										
K	2011	Silverado	Body	Memory Seat Module																																																										
K	2011	Silverado	Body	Park Assist Module																																																										
K	2011	Silverado	Body	Passenger Door Switch																																					V	V	V																			
K	2011	Silverado	Body	Passenger Presence System																																					V																					
K	2011	Silverado	Body	Radio																																																										
K	2011	Silverado	Body	Rear Heated Seat Module																																																										
K	2011	Silverado	Body	Rear HVAC/RSA																																																										
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2011	Silverado	Body	Theft Deterrent Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2011	Silverado Hybrid	Body	Body Control Module			V																																			V	V																		
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2011	Silverado Hybrid	Body	Driver Door Switch																																					V	V	V																			
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2011	Silverado Hybrid	Body	HVAC Control Module																																						V		V																		
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2011	Silverado Hybrid	Body	Park Assist Module																																																										
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																					V	V	V																			
K	2011	Silverado Hybrid	Body	Passenger Presence System																																					V																					
K	2011	Silverado Hybrid	Body	Radio																																																										
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																								
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																										V		V	V																											
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																							
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																							
K	2011	Tahoe	Chassis	Electronic Brake Control Module																																			V																					
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																							
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																							
K	2011	Tahoe	Body	Amplifier (Bose)																																																						
K	2011	Tahoe	Body	Assist Step Controller																																																						
K	2011	Tahoe	Body	Body Control Module			V																																			V	V																	
K	2011	Tahoe	Body	Body Control Module (aux.)																																																						
K	2011	Tahoe	Body	Digital Radio Receiver																																																						
K	2011	Tahoe	Body	Driver Door Switch																																					V	V	V																	
K	2011	Tahoe	Body	HVAC Control Module Auto																																						V		V																
K	2011	Tahoe	Body	HVAC Control Module Manual																																						V		V																
K	2011	Tahoe	Body	Instrument Panel Cluster																																																						
K	2011	Tahoe	Body	Left Side Object Detection Module																																																						
K	2011	Tahoe	Body	Lift Gate Module																																					V																		
K	2011	Tahoe	Body	Memory Seat Module																																																						
K	2011	Tahoe	Body	Park Assist Module																																																						
K	2011	Tahoe	Body	Passenger Door Switch																																					V	V	V																	
K	2011	Tahoe	Body	Passenger Presence System																																					V																		
K	2011	Tahoe	Body	Radio																																																						
K	2011	Tahoe	Body	Rear Heated Seat Module																																																						
K	2011	Tahoe	Body	Rear HVAC/RSA																																																						
K	2011	Tahoe	Body	Right Side Object Detection Module																																																						
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																						
K	2011	Tahoe	Body	Theft Deterrent Module																																																						
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																										V			V																											
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																						
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																						
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																						
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																						
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																						
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																						
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																						
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																						
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																						
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																						
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																						
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																						
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																						
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																						
K	2011	Tahoe Hybrid	Body	Body Control Module			V																																			V	V																	
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																						
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																						
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																					V	V	V																	
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																																						
K	2011	Tahoe Hybrid	Body	HVAC Control Module																																						V		V																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																									
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																					V																					
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																									
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																					V	V	V																			
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																					V																					
K	2011	Tahoe Hybrid	Body	Radio																																																									
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																									
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																									
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																									
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																												
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																V	V																								
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																									
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																									
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																								
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																									
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																									
K	2012	Avalanche	Chassis	Electronic Brake Control Module																																			V																					
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																									
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Avalanche	Body	Amplifier (Bose)																																																									
K	2012	Avalanche	Body	Assist Step Controller																																																									
K	2012	Avalanche	Body	Body Control Module			V																																			V	V																	
K	2012	Avalanche	Body	Body Control Module (aux.)																																																									
K	2012	Avalanche	Body	Digital Radio Receiver																																																									
K	2012	Avalanche	Body	Driver Door Switch																																					V	V	V																	
K	2012	Avalanche	Body	HVAC Control Module Auto																																						V		V																
K	2012	Avalanche	Body	HVAC Control Module Manual																																						V		V																
K	2012	Avalanche	Body	Instrument Panel Cluster																																																									
K	2012	Avalanche	Body	Memory Seat Module																																																									
K	2012	Avalanche	Body	Navigation Radio																																																									
K	2012	Avalanche	Body	Park Assist Module																																																									
K	2012	Avalanche	Body	Passenger Door Switch																																					V	V	V																	
K	2012	Avalanche	Body	Passenger Presence System																																					V																			
K	2012	Avalanche	Body	Radio																																																									
K	2012	Avalanche	Body	Rear Heated Seat Module																																																									
K	2012	Avalanche	Body	Rear HVAC/RSA																																																									
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																									
K	2012	Avalanche	Body	Theft Deterrent Module																																																									
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																											V		V	V																												
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																											V		V	V																												
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V										V																								
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																										V		V	V																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																							
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																V	V																							
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																			V																				
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																						
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																						
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																						
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																						
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																						
K	2012	Cheyenne	Body	Amplifier (Bose)																																																						
K	2012	Cheyenne	Body	Body Control Module			V																																			V	V																
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																						
K	2012	Cheyenne	Body	Digital Radio Receiver																																																						
K	2012	Cheyenne	Body	Driver Door Switch																																					V	V	V																
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																						
K	2012	Cheyenne	Body	Park Assist Module																																																						
K	2012	Cheyenne	Body	Passenger Door Switch																																					V	V	V																
K	2012	Cheyenne	Body	Passenger Presence System																																					V																	
K	2012	Cheyenne	Body	Rear Heated Seat Module																																																						
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																						
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																						
K	2012	Cheyenne	Body	Theft Deterrent Module																																																						
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																													V																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																						
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																						
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																										V		V	V																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																						
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																						
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																						
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																V	V																							
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																										V		V	V																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																						
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																							
K	2012	Suburban	Chassis	EBCM Under 8600 GVW																																			V																				
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																						
K	2012	Suburban	Chassis	Electronic Suspension Control																																																						
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																						
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																						
K	2012	Suburban	Body	Amplifier (Bose)																																																						
K	2012	Suburban	Body	Assist Step Controller																																																						
K	2012	Suburban	Body	Body Control Module			V																																			V	V																
K	2012	Suburban	Body	Body Control Module (aux.)																																																						
K	2012	Suburban	Body	Digital Radio Receiver																																																						
K	2012	Suburban	Body	Driver Door Switch																																					V	V	V																
K	2012	Suburban	Body	HVAC Control Module Auto																																						V		V															
K	2012	Suburban	Body	HVAC Control Module Manual																																						V		V															
K	2012	Suburban	Body	Instrument Panel Cluster																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2012	Suburban	Body	Left Side Object Detection Module																																																									
K	2012	Suburban	Body	Lift Gate Module																																				V																					
K	2012	Suburban	Body	Memory Seat Module																																																								
K	2012	Suburban	Body	Navigation Radio																																																								
K	2012	Suburban	Body	Park Assist Module																																																								
K	2012	Suburban	Body	Passenger Door Switch																																				V	V	V																			
K	2012	Suburban	Body	Passenger Presence System																																				V																					
K	2012	Suburban	Body	Radio																																																								
K	2012	Suburban	Body	Rear Heated Seat Module																																																								
K	2012	Suburban	Body	Rear HVAC/RSA																																																								
K	2012	Suburban	Body	Right Side Object Detection Module																																																								
K	2012	Suburban	Body	Supplemental Inflatable Restraint																																																								
K	2012	Suburban	Body	Theft Deterrent Module																																																								
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																										V		V	V																											
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																										V		V	V																											
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																										V		V	V																											
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																							
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																										V		V	V																											
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																							
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																										V		V	V																											
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																							
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																										V		V	V																											
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																										V		V	V																											
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																							
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																										V		V	V																											
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																							
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																										V			V																											
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																				V	V	V	V	V																																
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																										V			V																											
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																				V	V	V	V	V																																
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																			V																					
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																								
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2012	Silverado	Chassis	Electronic Suspension Control																																																								
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
K	2012	Silverado	Body	Amplifier (Bose)																																																								
K	2012	Silverado	Body	Body Control Module			V																																				V	V																
K	2012	Silverado	Body	Body Control Module (aux.)																																																								
K	2012	Silverado	Body	Digital Radio Receiver																																																								
K	2012	Silverado	Body	Driver Door Switch																																					V	V	V																	
K	2012	Silverado	Body	HVAC Control Module Auto																																						V		V																
K	2012	Silverado	Body	HVAC Control Module Manual																																						V		V																
K	2012	Silverado	Body	Instrument Panel Cluster																																																								
K	2012	Silverado	Body	Memory Seat Module																																																								
K	2012	Silverado	Body	Navigation Radio																																																								
K	2012	Silverado	Body	Park Assist Module																																																								
K	2012	Silverado	Body	Passenger Door Switch																																					V	V	V																	
K	2012	Silverado	Body	Passenger Presence System																																					V																			
K	2012	Silverado	Body	Radio																																																								
K	2012	Silverado	Body	Rear Heated Seat Module																																																								
K	2012	Silverado	Body	Rear HVAC/RSA																																																								
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																																								
K	2012	Silverado	Body	Theft Deterrent Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																								
K	2012	Silverado Hybrid	Body	Body Control Module			V																																			V	V																	
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																								
K	2012	Silverado Hybrid	Body	Driver Door Switch																																					V	V	V																	
K	2012	Silverado Hybrid	Body	Heated Seat Module																																																								
K	2012	Silverado Hybrid	Body	HVAC Control Module																																						V		V																
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
K	2012	Silverado Hybrid	Body	Navigation Radio																																																								
K	2012	Silverado Hybrid	Body	Park Assist Module																																																								
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																					V	V	V																	
K	2012	Silverado Hybrid	Body	Passenger Presence System																																					V																			
K	2012	Silverado Hybrid	Body	Radio																																																								
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																								
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																										V		V	V																											
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																							
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																							
K	2012	Tahoe	Chassis	EBCM with Trailer Brake																																			V																					
K	2012	Tahoe	Chassis	Electronic Suspension Control																																																							
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																							
K	2012	Tahoe	Body	Amplifier (Bose)																																																							
K	2012	Tahoe	Body	Assist Step Controller																																																							
K	2012	Tahoe	Body	Body Control Module			V																																			V	V																	
K	2012	Tahoe	Body	Body Control Module (aux.)																																																							
K	2012	Tahoe	Body	Digital Radio Receiver																																																							
K	2012	Tahoe	Body	Driver Door Switch																																					V	V	V																	
K	2012	Tahoe	Body	HVAC Control Module Auto																																						V		V																
K	2012	Tahoe	Body	HVAC Control Module Manual																																						V		V																
K	2012	Tahoe	Body	Instrument Panel Cluster																																																							
K	2012	Tahoe	Body	Left Side Object Detection Module																																																							
K	2012	Tahoe	Body	Lift Gate Module																																					V																			
K	2012	Tahoe	Body	Memory Seat Module																																																							
K	2012	Tahoe	Body	Navigation Radio																																																							
K	2012	Tahoe	Body	Park Assist Module																																																							
K	2012	Tahoe	Body	Passenger Door Switch																																					V	V	V																	
K	2012	Tahoe	Body	Passenger Presence System																																					V																			
K	2012	Tahoe	Body	Radio																																																							
K	2012	Tahoe	Body	Rear Heated Seat Module																																																							
K	2012	Tahoe	Body	Rear HVAC/RSA																																																							
K	2012	Tahoe	Body	Right Side Object Detection Module																																																							
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																							
K	2012	Tahoe	Body	Theft Deterrent Module																																																							
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																										V			V																											
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																							
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																							
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																							
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																							
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																							
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																							
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																							
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																							
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																							
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																							
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																							
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																							
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																							
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																							
K	2012	Tahoe Hybrid	Body	Body Control Module			V																																			V	V																	
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																							
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																							
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																					V	V	V																	
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2012	Tahoe Hybrid	Body	HVAC Control Module																																						V		V																
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																							
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																					V																				
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																								
K	2012	Tahoe Hybrid	Body	Park Assist Module																																																								
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																					V	V	V																		
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																					V																				
K	2012	Tahoe Hybrid	Body	Radio																																																								
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																											
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																V	V																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2013	Avalanche	Chassis	Electronic Brake Control Module																																			V																					
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																								
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Avalanche	Body	Amplifier (Bose)																																																								
K	2013	Avalanche	Body	Assist Step Controller																																																								
K	2013	Avalanche	Body	Body Control Module			V																																			V	V																	
K	2013	Avalanche	Body	Body Control Module (aux.)																																																								
K	2013	Avalanche	Body	Digital Radio Receiver																																																								
K	2013	Avalanche	Body	Driver Door Switch																																					V	V	V																		
K	2013	Avalanche	Body	HVAC Control Module Auto																																						V		V																	
K	2013	Avalanche	Body	HVAC Control Module Manual																																						V		V																	
K	2013	Avalanche	Body	Instrument Panel Cluster																																																								
K	2013	Avalanche	Body	Memory Seat Module																																																								
K	2013	Avalanche	Body	Navigation Radio																																																								
K	2013	Avalanche	Body	Park Assist Module																																																								
K	2013	Avalanche	Body	Passenger Door Switch																																					V	V	V																		
K	2013	Avalanche	Body	Passenger Presence System																																					V																				
K	2013	Avalanche	Body	Radio																																																								
K	2013	Avalanche	Body	Rear Heated Seat Module																																																								
K	2013	Avalanche	Body	Rear HVAC/RSA																																																								
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																								
K	2013	Avalanche	Body	Theft Deterrent Module																																																								
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																											V		V	V																											
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																											V		V	V																											
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V										V																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																										V		V	V																											
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																															V	V																								
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																							
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																										V		V	V																											
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																															V	V																								
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																							
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																		V																						
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																							
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																							
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																							
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																							
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																							
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																							
K	2013	Cheyenne	Body	Amplifier (Bose)																																																						
K	2013	Cheyenne	Body	Body Control Module			V																																			V	V																	
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																							
K	2013	Cheyenne	Body	Digital Radio Receiver																																																							
K	2013	Cheyenne	Body	Driver Door Switch																																					V	V	V																	
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																							
K	2013	Cheyenne	Body	Park Assist Module																																																							
K	2013	Cheyenne	Body	Passenger Door Switch																																					V	V	V																	
K	2013	Cheyenne	Body	Passenger Presence System																																					V																			
K	2013	Cheyenne	Body	Rear Heated Seat Module																																																							
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																							
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																							
K	2013	Cheyenne	Body	Theft Deterrent Module																																																							
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																										V		V	V																											
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																															V	V																								
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																							
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																							
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																													V																											
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																															V	V																								
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																							
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																							
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																										V		V	V																											
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																															V	V																								
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																							
K	2013	Suburban	Chassis	EBCM Under 8600 GVW																																		V																						
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																							
K	2013	Suburban	Chassis	Electronic Suspension Control																																																							
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																							
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																							
K	2013	Suburban	Body	Amplifier (Bose)																																																						
K	2013	Suburban	Body	Assist Step Controller																																																						
K	2013	Suburban	Body	Body Control Module			V																																			V	V																
K	2013	Suburban	Body	Body Control Module (aux.)																																																							
K	2013	Suburban	Body	Digital Radio Receiver																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2013	Suburban	Body	Driver Door Switch																																						V	V	V																
K	2013	Suburban	Body	HVAC Control Module Auto																																							V		V															
K	2013	Suburban	Body	HVAC Control Module Manual																																							V		V															
K	2013	Suburban	Body	Instrument Panel Cluster																																																							
K	2013	Suburban	Body	Left Side Object Detection Module																																																							
K	2013	Suburban	Body	Lift Gate Module																																						V																		
K	2013	Suburban	Body	Memory Seat Module																																																							
K	2013	Suburban	Body	Navigation Radio																																																							
K	2013	Suburban	Body	Park Assist Module																																																							
K	2013	Suburban	Body	Passenger Door Switch																																						V	V	V																	
K	2013	Suburban	Body	Passenger Presence System																																						V																		
K	2013	Suburban	Body	Radio																																																							
K	2013	Suburban	Body	Rear Heated Seat Module																																																							
K	2013	Suburban	Body	Rear HVAC/RSA																																																							
K	2013	Suburban	Body	Right Side Object Detection Module																																																							
K	2013	Suburban	Body	Supplemental Inflatable Restraint																																																							
K	2013	Suburban	Body	Theft Deterrent Module																																																							
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																											V		V	V																											
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																											V		V	V																											
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																							
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																											
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																							
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																								
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																							
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																											
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																							
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																							
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																							
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																							
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																											V		V	V																											
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																											V		V	V																											
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																							
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																							
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																											
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																							
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																	V	V																							
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																							
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																											
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																							
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																							
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																							
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																											V			V																											
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																							
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																							
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																				V	V	V	V	V																																
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																							
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																				V																				

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2013	Silverado	Chassis	Electronic Suspension Control																																																										
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2013	Silverado	Body	Amplifier (Bose)																																																										
K	2013	Silverado	Body	Body Control Module			V																																			V	V																		
K	2013	Silverado	Body	Body Control Module (aux.)																																																										
K	2013	Silverado	Body	Digital Radio Receiver																																																										
K	2013	Silverado	Body	Driver Door Switch																																					V	V	V																			
K	2013	Silverado	Body	HVAC Control Module Auto																																							V		V																	
K	2013	Silverado	Body	HVAC Control Module Manual																																							V		V																	
K	2013	Silverado	Body	Instrument Panel Cluster																																																										
K	2013	Silverado	Body	Memory Seat Module																																																										
K	2013	Silverado	Body	Navigation Radio																																																										
K	2013	Silverado	Body	Park Assist Module																																																										
K	2013	Silverado	Body	Passenger Door Switch																																					V	V	V																			
K	2013	Silverado	Body	Passenger Presence System																																					V																					
K	2013	Silverado	Body	Radio																																																										
K	2013	Silverado	Body	Rear Heated Seat Module																																																										
K	2013	Silverado	Body	Rear HVAC/RSA																																																										
K	2013	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2013	Silverado	Body	Theft Deterrent Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V		V																													
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2013	Silverado Hybrid	Body	Body Control Module			V																																			V	V																		
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2013	Silverado Hybrid	Body	Driver Door Switch																																					V	V	V																			
K	2013	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2013	Silverado Hybrid	Body	HVAC Control Module																																							V		V																	
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2013	Silverado Hybrid	Body	Navigation Radio																																																										
K	2013	Silverado Hybrid	Body	Park Assist Module																																																										
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																					V	V	V																			
K	2013	Silverado Hybrid	Body	Passenger Presence System																																					V																					

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2013	Silverado Hybrid	Body	Radio																																																								
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																														V																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2013	Tahoe	Chassis	Electronic Brake Control Module																																		V																						
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																								
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Tahoe	Body	Amplifier (Bose)																																																								
K	2013	Tahoe	Body	Assist Step Controller																																																								
K	2013	Tahoe	Body	Body Control Module			V																																				V	V																
K	2013	Tahoe	Body	Body Control Module (aux.)																																																								
K	2013	Tahoe	Body	Digital Radio Receiver																																																								
K	2013	Tahoe	Body	Driver Door Switch																																					V	V	V																	
K	2013	Tahoe	Body	HVAC Control Module Auto																																						V		V																
K	2013	Tahoe	Body	HVAC Control Module Manual																																						V		V																
K	2013	Tahoe	Body	Instrument Panel Cluster																																																								
K	2013	Tahoe	Body	Left Side Object Detection Module																																																								
K	2013	Tahoe	Body	Lift Gate Module																																					V																			
K	2013	Tahoe	Body	Memory Seat Module																																																								
K	2013	Tahoe	Body	Navigation Radio																																																								
K	2013	Tahoe	Body	Park Assist Module																																																								
K	2013	Tahoe	Body	Passenger Door Switch																																					V	V	V																	
K	2013	Tahoe	Body	Passenger Presence System																																					V																			
K	2013	Tahoe	Body	Radio																																																								
K	2013	Tahoe	Body	Rear Heated Seat Module																																																								
K	2013	Tahoe	Body	Rear HVAC/RSA																																																								
K	2013	Tahoe	Body	Right Side Object Detection Module																																																								
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																								
K	2013	Tahoe	Body	Theft Deterrent Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
K	2013	Tahoe Hybrid	Body	Body Control Module			V																																			V	V																		
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																					V	V	V																		
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																									
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																						V		V																		
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																									
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																					V																				
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																									
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																									
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																					V	V	V																		
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																					V																				
K	2013	Tahoe Hybrid	Body	Radio																																																									
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																									
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																									
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																									
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																									
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																									
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																									
K	2014	Cheyenne	Chassis	Power Steering Control Module																																																									
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2014	Cheyenne	Body	Body Control Module																																																									
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2014	Cheyenne	Body	Passenger Presence Module																																																									
K	2014	Cheyenne	Body	Instrument Cluster																																																									
K	2014	Cheyenne	Body	Radio Control																																																									
K	2014	Cheyenne	Body	HVAC Control																																																									
K	2014	Cheyenne	Body	Radio																																																									
K	2014	Cheyenne	Body	Amplifier																																																									
K	2014	Cheyenne	Body	Media Disc Player																																																									
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																									
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2014	Cheyenne	Body	HVAC Control Module																																																								
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																									
K	2014	Cheyenne	Body	Parking Assist Control Module																																																									
K	2014	Cheyenne	Body	Frontview Camera Module																																																									
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																									
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																									
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2014	Silverado	Chassis	Electronic Brake Control Module																																																									
K	2014	Silverado	Chassis	Parking Brake Control Module																																																									
K	2014	Silverado	Chassis	Power Steering Control Module																																																									
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2014	Silverado	Body	Body Control Module																																																									
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2014	Silverado	Body	Passenger Presence Module																																																									
K	2014	Silverado	Body	Instrument Cluster																																																									
K	2014	Silverado	Body	Radio Control																																																									
K	2014	Silverado	Body	HVAC Control																																																									
K	2014	Silverado	Body	Radio																																																									
K	2014	Silverado	Body	Amplifier																																																									
K	2014	Silverado	Body	Media Disc Player																																																									
K	2014	Silverado	Body	Human Machine Interface Control Module																																																									
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																									
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																									
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																									
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																									
K	2014	Silverado	Body	Parking Assist Control Module																																																									
K	2014	Silverado	Body	Frontview Camera Module																																																									
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																									
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																									
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																									
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																									
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																									
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2014	Silverado HD	Chassis	Suspension Control Module																																																									
K	2014	Silverado HD	Body	Body Control Module																																																									
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2014	Silverado HD	Body	Passenger Presence Module																																																									
K	2014	Silverado HD	Body	Instrument Cluster																																																									
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																									
K	2014	Silverado HD	Body	Base Radio																																																									
K	2014	Silverado HD	Body	Navigation Radio																																																									
K	2014	Silverado HD	Body	Uplevel Radio																																																									
K	2014	Silverado HD	Body	Amplifier																																																									
K	2014	Silverado HD	Body	Rear Audio Control Module																																																									
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																									
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																									
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																									
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																									
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																									
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																									
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																									
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																									
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																									
K	2014	Silverado HD	Body	Seat Memory Control Module																																																									
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																									
K	2014	Silverado HD	Body	Parking Assist Control Module																																																									
K	2014	Silverado HD	Body	Theft Deterrent Module																																																									
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																									
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																									
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																									
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																									
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																									
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																									
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																									
K	2014	Suburban	Chassis	Parking Brake Control Module																																																									
K	2014	Suburban	Chassis	Suspension Control Module																																																									
K	2014	Suburban	Body	Body Control Module																																																									
K	2014	Suburban	Body	Auxiliary Body Control Module																																																									
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2014	Suburban	Body	Passenger Presence Module																																																									
K	2014	Suburban	Body	Instrument Cluster																																																									
K	2014	Suburban	Body	Base Radio																																																									
K	2014	Suburban	Body	Navigation Radio																																																									
K	2014	Suburban	Body	Uplevel Radio																																																									
K	2014	Suburban	Body	Amplifier																																																									
K	2014	Suburban	Body	Rear Audio Control Module																																																									
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																									
K	2014	Suburban	Body	Personal Audio Link Control Module																																																									
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																									
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																								
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																								
K	2014	Suburban	Body	Liftgate Control Module																																																								
K	2014	Suburban	Body	Seat Memory Control Module																																																								
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																								
K	2014	Suburban	Body	Assist Step Control Module																																																								
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																								
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																								
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																								
K	2014	Suburban	Body	Parking Assist Control Module																																																								
K	2014	Suburban	Body	Theft Deterrent Module																																																								
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																								
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																								
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																								
K	2014	Tahoe	Chassis	Suspension Control Module																																																								
K	2014	Tahoe	Body	Body Control Module																																																								
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																								
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2014	Tahoe	Body	Passenger Presence Module																																																								
K	2014	Tahoe	Body	Instrument Cluster																																																								
K	2014	Tahoe	Body	Base Radio																																																								
K	2014	Tahoe	Body	Navigation Radio																																																								
K	2014	Tahoe	Body	Uplevel Radio																																																								
K	2014	Tahoe	Body	Amplifier																																																								
K	2014	Tahoe	Body	Rear Audio Control Module																																																								
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																								
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																								
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																								
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																								
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																								
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																								
K	2014	Tahoe	Body	Liftgate Control Module																																																								
K	2014	Tahoe	Body	Seat Memory Control Module																																																								
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																								
K	2014	Tahoe	Body	Assist Step Control Module																																																								
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																								
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																								
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																								
K	2014	Tahoe	Body	Parking Assist Control Module																																																								
K	2014	Tahoe	Body	Theft Deterrent Module																																																								
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																										
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																										
K	2015	Cheyenne	Chassis	Power Steering Control Module																																																										
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Cheyenne	Chassis	Suspension Control Module																																																										
K	2015	Cheyenne	Body	Body Control Module																																																										
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Cheyenne	Body	Passenger Presence Module																																																										
K	2015	Cheyenne	Body	Instrument Cluster																																																										
K	2015	Cheyenne	Body	Radio Controls																																																										
K	2015	Cheyenne	Body	HVAC Controls																																																										
K	2015	Cheyenne	Body	Radio																																																										
K	2015	Cheyenne	Body	Amplifier																																																										
K	2015	Cheyenne	Body	Media Disc Player																																																										
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																										
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
K	2015	Cheyenne	Body	HVAC Control Module																																																										
K	2015	Cheyenne	Body	Parking Assist Control Module																																																										
K	2015	Cheyenne	Body	Frontview Camera Module																																																										
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																									
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																									
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2015	Silverado	Chassis	Electronic Brake Control Module																																																									
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																									
K	2015	Silverado	Chassis	Power Steering Control Module																																																									
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2015	Silverado	Chassis	Suspension Control Module																																																									
K	2015	Silverado	Body	Body Control Module																																																									
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2015	Silverado	Body	Passenger Presence Module																																																									
K	2015	Silverado	Body	Instrument Cluster																																																									
K	2015	Silverado	Body	Radio Controls																																																									
K	2015	Silverado	Body	HVAC Controls																																																									
K	2015	Silverado	Body	Radio																																																									
K	2015	Silverado	Body	Amplifier																																																									
K	2015	Silverado	Body	Media Disc Player																																																									
K	2015	Silverado	Body	Human Machine Interface Control Module																																																									
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																																									
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																									
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																									
K	2015	Silverado	Body	Parking Assist Control Module																																																									
K	2015	Silverado	Body	Frontview Camera Module																																																									
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																									
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																									
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2015	Suburban	Chassis	Electronic Brake Control Module																																																									
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																									
K	2015	Suburban	Chassis	Parking Brake Control Module																																																									
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																									
K	2015	Suburban	Chassis	Power Steering Control Module																																																									
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2015	Suburban	Chassis	Suspension Control Module																																																									
K	2015	Suburban	Body	Body Control Module																																																									
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2015	Suburban	Body	Passenger Presence Module																																																									
K	2015	Suburban	Body	Instrument Cluster																																																									
K	2015	Suburban	Body	Radio Controls																																																									
K	2015	Suburban	Body	HVAC Controls																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2015	Suburban	Body	Radio																																																								
K	2015	Suburban	Body	Amplifier																																																								
K	2015	Suburban	Body	Media Disc Player																																																								
K	2015	Suburban	Body	Human Machine Interface Control Module																																																								
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																								
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																								
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																								
K	2015	Suburban	Body	HVAC Control Module																																																								
K	2015	Suburban	Body	Liftgate Control Module																																																								
K	2015	Suburban	Body	Keyless Entry Control Module																																																								
K	2015	Suburban	Body	Assist Step Control Module																																																								
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																								
K	2015	Suburban	Body	Parking Assist Control Module																																																								
K	2015	Suburban	Body	Frontview Camera Module																																																								
K	2015	Suburban	Body	Steering Column Lock Control Module																																																								
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																								
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																								
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																								
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																								
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																								
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																																								
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																								
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																								
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2015	Tahoe	Chassis	Power Steering Control Module																																																								
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2015	Tahoe	Chassis	Suspension Control Module																																																								
K	2015	Tahoe	Body	Body Control Module																																																								
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2015	Tahoe	Body	Passenger Presence Module																																																								
K	2015	Tahoe	Body	Instrument Cluster																																																								
K	2015	Tahoe	Body	Radio Controls																																																								
K	2015	Tahoe	Body	HVAC Controls																																																								
K	2015	Tahoe	Body	Radio																																																								
K	2015	Tahoe	Body	Amplifier																																																								
K	2015	Tahoe	Body	Media Disc Player																																																								
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																								
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																								
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																								
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																								
K	2015	Tahoe	Body	HVAC Control Module																																																								
K	2015	Tahoe	Body	Liftgate Control Module																																																								
K	2015	Tahoe	Body	Keyless Entry Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2015	Tahoe	Body	Assist Step Control Module																																																								
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																									
K	2015	Tahoe	Body	Parking Assist Control Module																																																									
K	2015	Tahoe	Body	Frontview Camera Module																																																									
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																									
K	2015	Tahoe	Body	Battery Energy Control Module																																																									
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																									
K	2016	Cheyenne	Chassis	Power Steering Control Module																																																									
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2016	Cheyenne	Chassis	Suspension Control Module																																																									
K	2016	Cheyenne	Body	Body Control Module																																																									
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2016	Cheyenne	Body	Passenger Presence Module																																																									
K	2016	Cheyenne	Body	Instrument Cluster																																																									
K	2016	Cheyenne	Body	Radio Controls																																																									
K	2016	Cheyenne	Body	HVAC Controls																																																									
K	2016	Cheyenne	Body	Radio																																																									
K	2016	Cheyenne	Body	Amplifier																																																									
K	2016	Cheyenne	Body	Media Disc Player																																																									
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																									
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																									
K	2016	Cheyenne	Body	HVAC Control Module																																																									
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																									
K	2016	Cheyenne	Body	Parking Assist Control Module																																																									
K	2016	Cheyenne	Body	Frontview Camera Module																																																									
K	2016	Cheyenne	Body	Frontview Camera Module																																																									
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																									
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2016	Silverado	Chassis	Power Steering Control Module																																																										
K	2016	Silverado	Chassis	Power Steering Control Module																																																										
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Silverado	Chassis	Suspension Control Module																																																										
K	2016	Silverado	Body	Body Control Module																																																										
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Silverado	Body	Passenger Presence Module																																																										
K	2016	Silverado	Body	Instrument Cluster																																																										
K	2016	Silverado	Body	Radio Controls																																																									
K	2016	Silverado	Body	HVAC Controls																																																									
K	2016	Silverado	Body	Radio (IO3)																																																									
K	2016	Silverado	Body	Radio (IOB)																																																									
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																									
K	2016	Silverado	Body	Amplifier																																																									
K	2016	Silverado	Body	Media Disc Player																																																									
K	2016	Silverado	Body	Human Machine Interface Control Module																																																										
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																										
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																										
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																										
K	2016	Silverado	Body	Parking Assist Control Module																																																										
K	2016	Silverado	Body	Frontview Camera Module																																																										
K	2016	Silverado	Body	Frontview Camera Module																																																										
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
K	2016	Suburban	Chassis	Parking Brake Control Module																																																										
K	2016	Suburban	Chassis	Power Steering Control Module																																																										
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Suburban	Chassis	Suspension Control Module																																																										
K	2016	Suburban	Body	Body Control Module																																																										
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2016	Suburban	Body	Passenger Presence Module																																																									
K	2016	Suburban	Body	Instrument Cluster																																																									
K	2016	Suburban	Body	Radio Controls																																																									
K	2016	Suburban	Body	HVAC Controls																																																									
K	2016	Suburban	Body	Radio																																																									
K	2016	Suburban	Body	Amplifier																																																									
K	2016	Suburban	Body	Media Disc Player																																																									
K	2016	Suburban	Body	Human Machine Interface Control Module																																																										
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																																										
K	2016	Suburban	Body	HVAC Control Module																																																										
K	2016	Suburban	Body	Liftgate Control Module																																																										
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																										
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																										
K	2016	Suburban	Body	Keyless Entry Control Module																																																										
K	2016	Suburban	Body	Assist Step Control Module																																																										
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																										
K	2016	Suburban	Body	Parking Assist Control Module																																																										
K	2016	Suburban	Body	Frontview Camera Module																																																										
K	2016	Suburban	Body	Steering Column Lock Control Module																																																										
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																										
K	2016	Tahoe	Chassis	Power Steering Control Module																																																										
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Tahoe	Chassis	Suspension Control Module																																																										
K	2016	Tahoe	Body	Body Control Module																																																										
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Tahoe	Body	Passenger Presence Module																																																										
K	2016	Tahoe	Body	Instrument Cluster																																																										
K	2016	Tahoe	Body	Radio Controls																																																										
K	2016	Tahoe	Body	HVAC Controls																																																										
K	2016	Tahoe	Body	Radio																																																										
K	2016	Tahoe	Body	Amplifier																																																										
K	2016	Tahoe	Body	Media Disc Player																																																										
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																										
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																										
K	2016	Tahoe	Body	HVAC Control Module																																																										
K	2016	Tahoe	Body	Liftgate Control Module																																																										
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																										
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																										
K	2016	Tahoe	Body	Keyless Entry Control Module																																																										
K	2016	Tahoe	Body	Assist Step Control Module																																																										
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2016	Tahoe	Body	Parking Assist Control Module																																																										
K	2016	Tahoe	Body	Frontview Camera Module																																																										
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																												

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																			
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
L	2004	ALL	Chassis	4WAL 3 Sensor																																																									
L	2004	ALL	Body	Body Control Module																																					V		V																		
L	2004	ALL	Body	Instrument Panel Cluster																																					V	V	V																		
L	2004	ALL	Body	Supplemental Inflatable Restraint																																					V	V																		
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																			
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
L	2005	Astro	Chassis	4WAL 3 Sensor																																																									
L	2005	Astro	Body	Body Control Module																																					V		V																		
L	2005	Astro	Body	Instrument Panel Cluster																																					V	V	V																		
L	2005	Astro	Body	Supplemental Inflatable Restraint																																					V	V																		
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																											V	V	V	V																											
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																V	V																								
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																																								
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																																								
L	2005	Equinox	Chassis	Electric Power Steering																																																								
L	2005	Equinox	Body	Body Control Module																																																								
L	2005	Equinox	Body	Instrument Panel Cluster																																																								
L	2005	Equinox	Body	Radio																																																								V
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																																								
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																											V	V	V	V																											
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																V	V																								
L	2006	ALL	Chassis	Traction Control Yes																																																								
L	2006	ALL	Chassis	Traction Control No																																																								
L	2006	ALL	Chassis	Electric Power Steering																																																								
L	2006	ALL	Body	Body Control Module																																																								
L	2006	ALL	Body	Instrument Panel Cluster																																																								
L	2006	ALL	Body	Radio																																																								V
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																											V	V	V	V																											
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																V																								
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																								
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																																								
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																																								
L	2007	ALL	Chassis	Power Steering Control Module																																																								
L	2007	ALL	Body	Body Control Module			V																																			V	V																	
L	2007	ALL	Body	Digital Radio Receiver																																																								
L	2007	ALL	Body	Heated Seat Module																																																								
L	2007	ALL	Body	HVAC Control Module																																							V		V																
L	2007	ALL	Body	Instrument Panel Cluster																																																								
L	2007	ALL	Body	Passenger Presence System																																					V																			
L	2007	ALL	Body	Radio																																																								
L	2007	ALL	Body	Rollover Sensor																																																								
L	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																			
L	2007	ALL	Body	Theft Deterrent Module																																																								
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																											V	V	V	V																											
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																V	V	V		V	V	V	V										V																								
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																											
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																V																								
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																																								
L	2008	Captiva Sport	Body	Body Control Module			V																																			V	V																	
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																								
L	2008	Captiva Sport	Body	HVAC Control Module Auto																																						V		V																
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																						V		V																
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																					V																		
L	2008	Captiva Sport	Body	Passenger Presence System																																					V																		
L	2008	Captiva Sport	Body	Radio																																																							
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																																							
L	2008	Captiva Sport	Body	Rollover Sensor																																																							
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																					V																		
L	2008	Captiva Sport	Body	Theft Deterrent Module																																																						
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																											V		V	V																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																							
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																V																								
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																							
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																V																								
L	2008	Equinox	Chassis	Electronic Brake Control Module																																																							
L	2008	Equinox	Chassis	Power Steering Control Module																																																							
L	2008	Equinox	Body	Body Control Module			V																																			V	V																	
L	2008	Equinox	Body	Digital Radio Receiver																																																							
L	2008	Equinox	Body	Heated Seat Module																																																							
L	2008	Equinox	Body	HVAC Control Module																																						V		V																
L	2008	Equinox	Body	Instrument Panel Cluster																																																							
L	2008	Equinox	Body	Passenger Presence System																																					V																		
L	2008	Equinox	Body	Radio																																																							
L	2008	Equinox	Body	Rollover Sensor																																																							
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																					V																		
L	2008	Equinox	Body	Theft Deterrent Module																																																							
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																											V		V	V																										
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																V	V	V		V	V	V	V		V							V																								
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																											V		V	V																										
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																V	V	V		V	V	V	V		V							V																								
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																											V		V	V																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																							
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																V																								
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																																							
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																							
L	2009	Captiva Sport	Body	Body Control Module			V																																			V	V																	
L	2009	Captiva Sport	Body	HVAC Control Module Auto																																						V		V																
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																						V		V																
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																					V																		
L	2009	Captiva Sport	Body	Passenger Presence System																																					V																		
L	2009	Captiva Sport	Body	Radio																																																						
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																																							
L	2009	Captiva Sport	Body	Rollover Sensor																																																							
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																					V																		
L	2009	Captiva Sport	Body	Theft Deterrent Module																																																							
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																											V		V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																								
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																	V																							
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																										V		V	V																											
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																							
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																	V																							
L	2009	Equinox	Chassis	Electronic Brake Control Module																																																							
L	2009	Equinox	Chassis	Power Steering Control Module																																																						
L	2009	Equinox	Body	Body Control Module			V																																			V	V																
L	2009	Equinox	Body	Digital Radio Receiver																																																						
L	2009	Equinox	Body	Heated Seat Module																																																						
L	2009	Equinox	Body	HVAC Control Module																																						V		V															
L	2009	Equinox	Body	Instrument Panel Cluster																																																						
L	2009	Equinox	Body	Passenger Presence System																																					V																		
L	2009	Equinox	Body	Radio																																																						
L	2009	Equinox	Body	Rollover Sensor																																																						
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																					V																		
L	2009	Equinox	Body	Theft Deterrent Module																																																						
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module																										V		V	V																											
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																						
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																V	V	V		V	V	V	V		V								V																							
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																										V		V	V																											
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																						
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																V	V	V		V	V	V	V		V								V																							
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																										V		V	V																											
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																						
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																						
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																	V	V																							
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																																						
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																						
L	2010	Captiva Sport	Body	Body Control Module			V																																			V	V																
L	2010	Captiva Sport	Body	HVAC Control Module																																							V		V															
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																					V																		
L	2010	Captiva Sport	Body	Passenger Presence System																																					V																		
L	2010	Captiva Sport	Body	Radio																																																						
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																																						
L	2010	Captiva Sport	Body	Rollover Sensor																																																						
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																					V																		
L	2010	Captiva Sport	Body	Theft Deterrent Module																																																						
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																						
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																						
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																						
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																						
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																						
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																						
L	2010	Equinox	Chassis	Electronic Brake Control Module																																																						
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																						
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																						
L	2010	Equinox	Body	Body Control Module																																																						
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
L	2010	Equinox	Body	Passenger Presence Module																																																						
L	2010	Equinox	Body	Instrument Cluster																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2010	Equinox	Body	Radio																																																								
L	2010	Equinox	Body	Multimedia Player Interface Module																																																								
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																																								
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																																								
L	2010	Equinox	Body	Liftgate Control Module																																																								
L	2010	Equinox	Body	Parking Assist Control Module																																																								
L	2010	Equinox	Body	Frontview Camera Module																																																								
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																																								
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																								
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																								
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																								
L	2011	Captiva	Chassis	Electronic Brake Control Module																																																								
L	2011	Captiva	Chassis	Parking Brake Control Module																																																								
L	2011	Captiva	Body	Body Control Module																																																								
L	2011	Captiva	Body	Auxiliary Body Control Module																																																								
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2011	Captiva	Body	Instrument Cluster																																																								
L	2011	Captiva	Body	Headlamp Control Module																																																								
L	2011	Captiva	Body	HVAC Control Module																																																								
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																								
L	2011	Captiva	Body	Parking Assist Control Module																																																								
L	2011	Captiva	Body	Theft Deterrent Module																																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module																											V	V	V	V																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																V	V																							
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module																											V	V	V	V																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																V	V																							
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																											V	V	V	V																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																V	V																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module																																																								
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																																									
L	2011	Captiva Sport	Body	Body Control Module			V																																			V	V																		
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																								
L	2011	Captiva Sport	Body	HVAC Control Module																																						V		V																	
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																				V																				
L	2011	Captiva Sport	Body	Passenger Presence System																																				V																				
L	2011	Captiva Sport	Body	Radio																																																								
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																																								
L	2011	Captiva Sport	Body	Rollover Sensor																																																								
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																																																								
L	2011	Captiva Sport	Body	Theft Deterrent Module																																																								
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																																								
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																								
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																								
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																								
L	2011	Equinox	Chassis	Electronic Brake Control Module																																																								
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2011	Equinox	Body	Body Control Module																																																								
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2011	Equinox	Body	Passenger Presence Module																																																								
L	2011	Equinox	Body	Instrument Cluster																																																								
L	2011	Equinox	Body	Radio																																																								
L	2011	Equinox	Body	Multimedia Player Interface Module																																																								
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																																								
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																																								
L	2011	Equinox	Body	Liftgate Control Module																																																								
L	2011	Equinox	Body	Parking Assist Control Module																																																								
L	2011	Equinox	Body	Frontview Camera Module																																																								
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																																																								
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																								
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																								
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																								
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																								
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																								
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																								
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																								
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																								
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																								
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
L	2012	Captiva	Chassis	Electronic Brake Control Module																																																										
L	2012	Captiva	Chassis	Parking Brake Control Module																																																										
L	2012	Captiva	Body	Body Control Module																																																										
L	2012	Captiva	Body	Auxiliary Body Control Module																																																										
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2012	Captiva	Body	Instrument Cluster																																																										
L	2012	Captiva	Body	Headlamp Control Module																																																										
L	2012	Captiva	Body	HVAC Control Module																																																										
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																										
L	2012	Captiva	Body	Parking Assist Control Module																																																										
L	2012	Captiva	Body	Theft Deterrent Module																																																										
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																											V	V	V	V																												
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																										
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																										
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																										
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																											V	V	V	V																												
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																										
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																										
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																																										
L	2012	Captiva Sport	Body	Body Control Module			V																																				V	V																		
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2012	Captiva Sport	Body	HVAC Control Module																																							V		V																	
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																					V																				
L	2012	Captiva Sport	Body	Passenger Presence System																																					V																				
L	2012	Captiva Sport	Body	Radio																																																									
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2012	Captiva Sport	Body	Rollover Sensor																																																										
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2012	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																										
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2012	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2012	Equinox	Body	Body Control Module																																																										
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2012	Equinox	Body	Passenger Presence Module																																																										
L	2012	Equinox	Body	Instrument Cluster																																																										
L	2012	Equinox	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2012	Equinox	Body	Multimedia Player Interface Module																																																								
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																								
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																								
L	2012	Equinox	Body	Liftgate Control Module																																																								
L	2012	Equinox	Body	Parking Assist Control Module																																																								
L	2012	Equinox	Body	Frontview Camera Module																																																								
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																																								
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																								
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																								
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																								
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																								
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																								
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																								
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																								
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																								
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																								
L	2013	Captiva	Chassis	Parking Brake Control Module																																																								
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																								
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																								
L	2013	Captiva	Body	Auxiliary Body Control Module																																																								
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2013	Captiva	Body	Instrument Cluster																																																								
L	2013	Captiva	Body	Headlamp Control Module																																																								
L	2013	Captiva	Body	HVAC Control Module																																																								
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																								
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																								
L	2013	Captiva	Body	Theft Deterrent Module																																																								
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																											V	V	V	V																										
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																								
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																								
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																											V	V	V	V																										
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																								
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																								
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																																								
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																								
L	2013	Captiva Sport	Body	Body Control Module			V																																			V	V																	
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																								
L	2013	Captiva Sport	Body	Heated Seat Module																																																								
L	2013	Captiva Sport	Body	HVAC Control Module																																						V		V																
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																					V																			

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2013	Captiva Sport	Body	Park Assist Module																																																								
L	2013	Captiva Sport	Body	Passenger Presence System																																					V																				
L	2013	Captiva Sport	Body	Radio																																																								
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																								
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																																								
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																								
L	2013	Captiva Sport	Body	Theft Deterrent Module																																																								
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																								
L	2013	Equinox	Chassis	Electronic Brake Control Module																																																								
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2013	Equinox	Chassis	Power Steering Control Module																																																								
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																								
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																								
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2013	Equinox	Body	Passenger Presence Module																																																								
L	2013	Equinox	Body	Instrument Cluster																																																								
L	2013	Equinox	Body	Radio																																																								
L	2013	Equinox	Body	Rear Audio Control Module																																																								
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																								
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																								
L	2013	Equinox	Body	Liftgate Control Module																																																								
L	2013	Equinox	Body	Front Seat Heating Control Module																																																								
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																								
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																								
L	2013	Equinox	Body	Parking Assist Control Module																																																								
L	2013	Equinox	Body	Frontview Camera Module																																																								
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																								
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																								
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																								
L	2014	Captiva (3GN)	Body	Body Control Module																																																								
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																								
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																								
L	2014	Captiva (3GN)	Body	Radio																																																								
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																								
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																								
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																								
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																									
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																										
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Captiva (Other)	Body	Instrument Cluster																																																										
L	2014	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2014	Captiva (Other)	Body	HVAC Control Module																																																										
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2014	Captiva (Other)	Body	Theft Deterrent Module																																																										
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2014	Equinox	Chassis	Power Steering Control Module																																																										
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Equinox	Body	Passenger Presence Module																																																										
L	2014	Equinox	Body	Instrument Cluster																																																										
L	2014	Equinox	Body	Radio																																																										
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2014	Equinox	Body	Liftgate Control Module																																																									
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Parking Assist Control Module																																																										
L	2014	Equinox	Body	Frontview Camera Module																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (3GN)	Body	Body Control Module																																																										
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																																										
L	2015	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2015	Captiva (3GN)	Body	Radio																																																										
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
L	2015	Captiva (3GN)	Body	HVAC Control Module																																																										
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (Other)	Body	Instrument Cluster																																																										
L	2015	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2015	Captiva (Other)	Body	HVAC Control Module																																																										
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																									
L	2015	Captiva (Other)	Body	Theft Deterrent Module																																																										
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2015	Equinox	Chassis	Power Steering Control Module																																																										
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Equinox	Body	Passenger Presence Module																																																										
L	2015	Equinox	Body	Instrument Cluster																																																										
L	2015	Equinox	Body	Radio																																																										
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																																										
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2015	Equinox	Body	Liftgate Control Module																																																										
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2015	Equinox	Body	Parking Assist Control Module																																																										
L	2015	Equinox	Body	Frontview Camera Module																																																										
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2016	Captiva (3GN)	Body	Body Control Module																																																										
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2016	Captiva (3GN)	Body	Radio																																																										
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
L	2016	Captiva (3GN)	Body	HVAC Control Module																																																										
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																										
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Captiva (Other)	Body	Instrument Cluster																																																										
L	2016	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2016	Captiva (Other)	Body	Radio																																																										
L	2016	Captiva (Other)	Body	HVAC Control Module																																																										
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2016	Captiva (Other)	Body	Theft Deterrent Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2016	Equinox	Chassis	Power Steering Control Module																																																										
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Equinox	Body	Passenger Presence Module																																																										
L	2016	Equinox	Body	Instrument Cluster																																																										
L	2016	Equinox	Body	Radio																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2016	Equinox	Body	Liftgate Control Module																																																										
L	2016	Equinox	Body	Seat Memory Control Module																																																										
L	2016	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Parking Assist Control Module																																																										
L	2016	Equinox	Body	Frontview Camera Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																											
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																			

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
M	2004	ALL	Chassis	4WAL 3 Sensor																																																								
M	2004	ALL	Body	Body Control Module																																				V		V																		
M	2004	ALL	Body	Instrument Panel Cluster																																				V	V	V																		
M	2004	ALL	Body	Supplemental Inflatable Restraint																																				V	V																		
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																									
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
M	2005	ALL	Chassis	4WAL 3 Sensor																																																								
M	2005	ALL	Body	Body Control Module																																				V		V																		
M	2005	ALL	Body	Instrument Panel Cluster																																				V	V	V																		
M	2005	ALL	Body	Supplemental Inflatable Restraint																																				V	V																		
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module													V	V																																									
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module													V	V																																									
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module													V	V																																									
P	2007	ALL	Body	Supplemental Inflatable Restraint																																				V																				V
P	2007	ALL	Body	Theft Deterrent Module																																				V																			
R	2009	ALL	Powertrain	Engine Control Module																										V		V	V																											
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																							
R	2009	ALL	Powertrain	Transmission Control Module																																V																								
R	2009	ALL	Chassis	Electronic Brake Control Module																																			V																				
R	2009	ALL	Body	Body Control Module			V																																		V	V																	
R	2009	ALL	Body	Digital Radio Receiver																																																						
R	2009	ALL	Body	Driver Door Switch																																				V	V	V																	
R	2009	ALL	Body	Heated Seat Module																																																						
R	2009	ALL	Body	HVAC Control Module Auto																																						V		V															
R	2009	ALL	Body	HVAC Control Module Manual																																						V		V															
R	2009	ALL	Body	Instrument Panel Cluster																																																						
R	2009	ALL	Body	Lift Gate Module																																				V																			
R	2009	ALL	Body	Park Assist Module																																																						
R	2009	ALL	Body	Passenger Door Switch																																				V	V	V																	
R	2009	ALL	Body	Passenger Presence System																																				V																			
R	2009	ALL	Body	Radio																																																						
R	2009	ALL	Body	Rear HVAC/RSA																																																						
R	2009	ALL	Body	Rollover Sensor																																																						
R	2009	ALL	Body	Supplemental Inflatable Restraint																																				V																			
R	2009	ALL	Body	Theft Deterrent Module																																																						
R	2010	ALL	Powertrain	Engine Control Module																										V	V	V	V																											
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																							
R	2010	ALL	Powertrain	Transmission Control Module																																V	V																							
R	2010	ALL	Chassis	Electronic Brake Control Module																																			V																			
R	2010	ALL	Body	Body Control Module			V																																		V	V																	
R	2010	ALL	Body	Digital Radio Receiver																																																						
R	2010	ALL	Body	Driver Door Switch																																				V	V	V																	
R	2010	ALL	Body	Heated Seat Module																																																						
R	2010	ALL	Body	HVAC Control Module Auto																																						V		V															
R	2010	ALL	Body	HVAC Control Module Manual																																						V		V															
R	2010	ALL	Body	Instrument Panel Cluster																																																						
R	2010	ALL	Body	Lift Gate Module																																				V																			
R	2010	ALL	Body	Park Assist Module																																																						
R	2010	ALL	Body	Passenger Door Switch																																				V	V	V																	
R	2010	ALL	Body	Passenger Presence System																																				V																			
R	2010	ALL	Body	Radio																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2010	ALL	Body	Rear HVAC/RSA																																																								
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2010	ALL	Body	Theft Deterrent Module																																																									
R	2011	ALL	Powertrain	Engine Control Module																											V	V	V	V																												
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2011	ALL	Powertrain	Transmission Control Module																																	V	V																								
R	2011	ALL	Chassis	Electronic Brake Control Module																																			V																						
R	2011	ALL	Body	Body Control Module			V																																			V	V																		
R	2011	ALL	Body	Digital Radio Receiver																																																									
R	2011	ALL	Body	Driver Door Switch																																					V	V	V																			
R	2011	ALL	Body	Heated Seat Module																																																									
R	2011	ALL	Body	HVAC Control Module Auto																																						V		V																		
R	2011	ALL	Body	HVAC Control Module Manual																																						V		V																		
R	2011	ALL	Body	Instrument Panel Cluster																																																									
R	2011	ALL	Body	Lift Gate Module																																					V																				
R	2011	ALL	Body	Park Assist Module																																																									
R	2011	ALL	Body	Passenger Door Switch																																					V	V	V																		
R	2011	ALL	Body	Passenger Presence System																																					V																				
R	2011	ALL	Body	Radio																																																									
R	2011	ALL	Body	Rear HVAC/RSA																																																									
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2011	ALL	Body	Theft Deterrent Module																																																									
R	2012	ALL	Powertrain	Engine Control Module																											V	V	V	V																												
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2012	ALL	Powertrain	Transmission Control Module																																	V	V																								
R	2012	ALL	Chassis	Electronic Brake Control Module																																			V																						
R	2012	ALL	Body	Body Control Module			V																																			V	V																		
R	2012	ALL	Body	Digital Radio Receiver																																																									
R	2012	ALL	Body	Driver Door Switch																																					V	V	V																		
R	2012	ALL	Body	Heated Seat Module																																																									
R	2012	ALL	Body	HVAC Control Module Auto																																						V		V																		
R	2012	ALL	Body	HVAC Control Module Manual																																						V		V																		
R	2012	ALL	Body	Instrument Panel Cluster																																																									
R	2012	ALL	Body	Lift Gate Module																																					V																				
R	2012	ALL	Body	Park Assist Module																																																									
R	2012	ALL	Body	Passenger Door Switch																																					V	V	V																		
R	2012	ALL	Body	Passenger Presence System																																					V																				
R	2012	ALL	Body	Radio																																																									
R	2012	ALL	Body	Rear HVAC/RSA																																																									
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2012	ALL	Body	Theft Deterrent Module																																																									
R	2013	ALL	Powertrain	Engine Control Module																											V	V	V	V																												
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2013	ALL	Powertrain	Transmission Control Module																																	V	V																								
R	2013	ALL	Chassis	Electronic Brake Control Module																																			V																						
R	2013	ALL	Body	Body Control Module			V																																			V	V																		
R	2013	ALL	Body	Digital Radio Receiver																																																									
R	2013	ALL	Body	Driver Door Switch																																					V	V	V																		
R	2013	ALL	Body	Heated Seat Module																																																									
R	2013	ALL	Body	HVAC Control Module Auto																																						V		V																		
R	2013	ALL	Body	HVAC Control Module Manual																																						V		V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2013	ALL	Body	Instrument Panel Cluster																																																									
R	2013	ALL	Body	Left Side Object Detection Module																																																										
R	2013	ALL	Body	Lift Gate Module																																					V																					
R	2013	ALL	Body	Park Assist Module																																																									
R	2013	ALL	Body	Passenger Door Switch																																					V	V	V																			
R	2013	ALL	Body	Passenger Presence System																																					V																					
R	2013	ALL	Body	Radio																																																									
R	2013	ALL	Body	Rear HVAC/RSA																																																										
R	2013	ALL	Body	Right Side Object Detection Module																																																										
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2013	ALL	Body	Theft Deterrent Module																																																										
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2014	Traverse	Powertrain	Chassis Control Module																																																										
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2014	Traverse	Chassis	Electronic Brake Control Module																																																										
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2014	Traverse	Body	Passenger Presence Module																																																										
R	2014	Traverse	Body	Instrument Cluster																																																										
R	2014	Traverse	Body	Radio																																																										
R	2014	Traverse	Body	Rear Audio Control Module																																																										
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																										
R	2014	Traverse	Body	Personal Audio Link Control Module																																																										
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																										
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
R	2014	Traverse	Body	Liftgate Control Module																																																										
R	2014	Traverse	Body	Seat Memory Control Module																																																										
R	2014	Traverse	Body	Front Seat Heating Control Module																																																										
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2014	Traverse	Body	Parking Assist Control Module																																																										
R	2014	Traverse	Body	Frontview Camera Module																																																										
R	2014	Traverse	Body	Theft Deterrent Module																																																										
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2015	Traverse	Chassis	Electronic Brake Control Module																																																										
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	Traverse	Body	Passenger Presence Module																																																										
R	2015	Traverse	Body	Instrument Cluster																																																										
R	2015	Traverse	Body	Radio																																																										
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																								
R	2015	Traverse	Body	Liftgate Control Module																																																								
R	2015	Traverse	Body	Seat Memory Control Module																																																								
R	2015	Traverse	Body	Front Seat Heating Control Module																																																								
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																								
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																								
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																								
R	2015	Traverse	Body	Parking Assist Control Module																																																								
R	2015	Traverse	Body	Frontview Camera Module																																																								
R	2015	Traverse	Body	Theft Deterrent Module																																																								
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																								
R	2016	Traverse	Chassis	Electronic Brake Control Module																																																								
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																								
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																								
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2016	Traverse	Body	Passenger Presence Module																																																								
R	2016	Traverse	Body	Instrument Cluster																																																								
R	2016	Traverse	Body	Radio																																																								
R	2016	Traverse	Body	Rear Audio Control Module																																																								
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																								
R	2016	Traverse	Body	Personal Audio Link Control Module																																																								
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																								
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																								
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																								
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																								
R	2016	Traverse	Body	Liftgate Control Module																																																								
R	2016	Traverse	Body	Seat Memory Control Module																																																								
R	2016	Traverse	Body	Front Seat Heating Control Module																																																								
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																								
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																								
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																								
R	2016	Traverse	Body	Parking Assist Control Module																																																								
R	2016	Traverse	Body	Frontview Camera Module																																																								
R	2016	Traverse	Body	Theft Deterrent Module																																																								
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
S	2004	S10	Chassis	4WAL 3 Sensor																																																								
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																								
S	2004	S10	Body	Body Control Module																																				V		V																		
S	2004	S10	Body	Instrument Panel Cluster																																				V	V	V																		
S	2004	S10	Body	Base Radio																																																								
S	2004	S10	Body	Uplevel Radio																																																								
S	2004	S10	Body	Supplemental Inflatable Restraint																																				V	V																			
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module													V	V	V																																									
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																V	V	V		V	V	V																																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module													V	V	V																																									
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																V	V	V		V	V	V																																		
S	2004	Colorado	Chassis	ABS Without Traction Control																																																									
S	2004	Colorado	Chassis	ABS With Traction Control																																																									
S	2004	Colorado	Body	Body Control Module																																					V	V	V																		
S	2004	Colorado	Body	Instrument Panel Cluster																																					V	V																		
S	2004	Colorado	Body	OnStar																																																								
S	2004	Colorado	Body	Base Radio																																																								
S	2004	Colorado	Body	Uplevel Radio																																																								
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																					V																				V
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																								
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																								
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																								
S	2004	TrailBlazer	Body	Body Control Module																																																								
S	2004	TrailBlazer	Body	Driver Door Module																																					V	V	V																		
S	2004	TrailBlazer	Body	Driver Seat Module																																																								
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																								
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																								
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																																								
S	2004	TrailBlazer	Body	Lift Gate Module																																																								
S	2004	TrailBlazer	Body	OnStar																																																								
S	2004	TrailBlazer	Body	Passenger Door Module																																					V	V	V																		
S	2004	TrailBlazer	Body	Uplevel Radio																																																								
S	2004	TrailBlazer	Body	Navigation Radio																																																								
S	2004	TrailBlazer	Body	Rear Seat Audio																																																								
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																								
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																					V	V																		
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																					V																		
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module													V	V																																									
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																V	V	V		V	V	V																																		
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																								
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																								
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																								
S	2004	TrailBlazer EXT	Body	Body Control Module																																																								
S	2004	TrailBlazer EXT	Body	Driver Door Module																																					V	V	V																		
S	2004	TrailBlazer EXT	Body	Driver Seat Module																																																								
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																								
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																								
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																								
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																								
S	2004	TrailBlazer EXT	Body	OnStar																																																								
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																					V	V	V																		
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																								
S	2004	TrailBlazer EXT	Body	Navigation Radio																																																								
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																								
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																								
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																					V	V																		
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																					V																			
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																								
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																								
S	2004	Blazer	Body	Body Control Module																																					V		V																	
S	2004	Blazer	Body	Heating and Air Conditioning																																																								
S	2004	Blazer	Body	Instrument Panel Cluster																																					V	V	V																	
S	2004	Blazer	Body	Memory Seat Module																																					V	V	V																	
S	2004	Blazer	Body	Base Radio																																																								
S	2004	Blazer	Body	Uplevel Radio																																																								
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																					V	V																		
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module													V	V																																										
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																V	V	V		V	V	V																																		
S	2004	SSR	Chassis	4WAL 3 Sensor																																																								
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																								
S	2004	SSR	Body	Amplifier (Bose)																																																								
S	2004	SSR	Body	Body Control Module																																					V	V	V																	
S	2004	SSR	Body	Driver Seat Module																																																								
S	2004	SSR	Body	Instrument Panel Cluster																																																								
S	2004	SSR	Body	Uplevel Radio																																																								
S	2004	SSR	Body	Remote Function Actuation																																																								
S	2004	SSR	Body	Roof and Door Module																																					V	V	V				V													
S	2004	SSR	Body	Supplemental Inflatable Restraint																																					V	V																		
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module													V	V	V																																									
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																V	V	V		V	V	V																																		
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module													V	V	V																																									
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																V	V	V		V	V	V																																		
S	2005	Colorado	Chassis	ABS Without Traction Control																																																								
S	2005	Colorado	Chassis	ABS With Traction Control																																																								
S	2005	Colorado	Body	Body Control Module																																					V	V	V																	
S	2005	Colorado	Body	Instrument Panel Cluster																																					V	V																		
S	2005	Colorado	Body	Base Radio																																																								
S	2005	Colorado	Body	Uplevel Radio																																																								
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																					V																			V
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																																								
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																								
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																								
S	2005	TrailBlazer	Body	Body Control Module																																																								
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																								
S	2005	TrailBlazer	Body	Driver Door Module																																					V	V	V																	
S	2005	TrailBlazer	Body	Driver Seat Module																																																								
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																								
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																								
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2005	TrailBlazer	Body	Lift Gate Module																																																							
S	2005	TrailBlazer	Body	Passenger Door Module																																				V	V	V																	
S	2005	TrailBlazer	Body	Passenger Presence System																																																							
S	2005	TrailBlazer	Body	Uplevel Radio																																																							
S	2005	TrailBlazer	Body	Navigation Radio																																																							
S	2005	TrailBlazer	Body	Rear Seat Audio																																																							
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																				V																			V
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																						
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																				V																			
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																								
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V												V																								
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																							
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																							
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																							
S	2005	TrailBlazer EXT	Body	Body Control Module																																																							
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																							
S	2005	TrailBlazer EXT	Body	Driver Door Module																																				V	V	V																	
S	2005	TrailBlazer EXT	Body	Driver Seat Module																																																							
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																							
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																							
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																							
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																							
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																				V	V	V																	
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																							
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																							
S	2005	TrailBlazer EXT	Body	Navigation Radio																																																							
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																							
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																							
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																							
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																				V																			V
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																							
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																				V																			
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																									
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																	
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																							
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																							
S	2005	Blazer	Body	Body Control Module																																				V		V																	
S	2005	Blazer	Body	Heating and Air Conditioning																																																							
S	2005	Blazer	Body	Instrument Panel Cluster																																				V	V	V																	
S	2005	Blazer	Body	Memory Seat Module																																				V	V	V																	
S	2005	Blazer	Body	Base Radio																																																							
S	2005	Blazer	Body	Uplevel Radio																																																							
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																				V	V																		
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																									
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V												V																								
S	2005	SSR	Chassis	4WAL 3 Sensor																																																							
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																							
S	2005	SSR	Body	Amplifier (Bose)																																																							
S	2005	SSR	Body	Body Control Module																																				V	V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2005	SSR	Body	Driver Seat Module																																																							
S	2005	SSR	Body	Instrument Panel Cluster																																																						
S	2005	SSR	Body	Uplevel Radio																																																						
S	2005	SSR	Body	Remote Function Actuation																																																						
S	2005	SSR	Body	Roof and Door Module																																						V	V					V											
S	2005	SSR	Body	Supplemental Inflatable Restraint																																					V																		V
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module													V	V	V																																							
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																V	V	V		V	V	V																																
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module													V	V	V																																							
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																V	V	V		V	V	V																																
S	2006	Colorado	Chassis	ABS Without Traction Control																																																						
S	2006	Colorado	Chassis	ABS With Traction Control																																																						
S	2006	Colorado	Body	Body Control Module																																					V	V	V																
S	2006	Colorado	Body	Instrument Panel Cluster																																					V	V																	
S	2006	Colorado	Body	Passenger Presence System																																																						
S	2006	Colorado	Body	Base Radio																																																						
S	2006	Colorado	Body	Uplevel Radio																																																						
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																					V																		V
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																																						
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																								
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V												V																							
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																									
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V												V																							
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																						
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																						
S	2006	TrailBlazer	Body	Body Control Module																																					V	V	V																
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																						
S	2006	TrailBlazer	Body	Driver Door Module																																					V	V	V																
S	2006	TrailBlazer	Body	Driver Seat Module																																																						
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																						
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																						
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																																						
S	2006	TrailBlazer	Body	Lift Gate Module																																																						
S	2006	TrailBlazer	Body	Passenger Door Module																																					V	V	V																
S	2006	TrailBlazer	Body	Passenger Presence System																																																						
S	2006	TrailBlazer	Body	Uplevel Radio																																																						
S	2006	TrailBlazer	Body	Navigation Radio																																																						
S	2006	TrailBlazer	Body	Rear Seat Audio																																																						
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																					V																		V
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																					V																		
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																						
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																								
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V												V																							
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																					
S	2006	TrailBlazer EXT	Body	Body Control Module																																					V	V	V																
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																					
S	2006	TrailBlazer EXT	Body	Driver Door Module																																					V	V	V																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2006	TrailBlazer EXT	Body	Driver Seat Module																																																							
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																							
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																							
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																							
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																							
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																					V	V	V																	
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																							
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																							
S	2006	TrailBlazer EXT	Body	Navigation Radio																																																							
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																							
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																							
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																							
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																					V																		V
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																					V																		
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																							
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																										
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V													V																							
S	2006	SSR	Chassis	4WAL 3 Sensor																																																							
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																							
S	2006	SSR	Body	Amplifier (Bose)																																																						
S	2006	SSR	Body	Body Control Module																																					V	V	V																	
S	2006	SSR	Body	Driver Seat Module																																																							
S	2006	SSR	Body	Instrument Panel Cluster																																																							
S	2006	SSR	Body	Uplevel Radio																																																							
S	2006	SSR	Body	Remote Function Actuation																																																							
S	2006	SSR	Body	Roof and Door Module																																						V	V					V											
S	2006	SSR	Body	Supplemental Inflatable Restraint																																					V																		V
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V		V	V																										
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V																																	
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V		V	V																										
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V																																	
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																							
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																							
S	2007	Colorado	Body	Body Control Module																																					V	V	V																	
S	2007	Colorado	Body	Digital Radio Receiver																																																							
S	2007	Colorado	Body	Generator Battery Control Module																																																							
S	2007	Colorado	Body	Instrument Panel Cluster																																					V	V																		
S	2007	Colorado	Body	Passenger Presence System																																																							
S	2007	Colorado	Body	Base Radio																																																							
S	2007	Colorado	Body	Uplevel Radio																																																							
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																					V																		V
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																																							
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																											V		V	V																										
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																											V		V	V																										
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																V	V	V		V	V	V																																	
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V																																			
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																										
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V																																			
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2007	Trailblazer	Body	Body Control Module																																					V	V	V																
S	2007	Trailblazer	Body	Digital Radio Receiver																																																						
S	2007	Trailblazer	Body	Disc Player and Video Display																																																						
S	2007	Trailblazer	Body	Driver Door Module																																					V	V	V																
S	2007	Trailblazer	Body	Driver Seat Module																																																						
S	2007	Trailblazer	Body	Generator Battery Control Module																																																						
S	2007	Trailblazer	Body	HVAC Control Module Auto																																																						
S	2007	Trailblazer	Body	HVAC Control Module Manual																																																						
S	2007	Trailblazer	Body	Instrument Panel Cluster																																																						
S	2007	Trailblazer	Body	Lift Gate Module																																					V																		
S	2007	Trailblazer	Body	Passenger Door Module																																					V	V	V																
S	2007	Trailblazer	Body	Passenger Presence System																																																						
S	2007	Trailblazer	Body	Uplevel Radio																																																						
S	2007	Trailblazer	Body	Navigation Radio																																																						
S	2007	Trailblazer	Body	Rear Seat Audio																																																						
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																					V																		V
S	2007	Trailblazer	Body	Theft Deterrent Module																																					V																		
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																						
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																									
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V																																			
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V																																			
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																						
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																						
S	2008	Colorado	Body	Body Control Module																																					V	V	V																
S	2008	Colorado	Body	Digital Radio Receiver																																																						
S	2008	Colorado	Body	Generator Battery Control Module																																																						
S	2008	Colorado	Body	Instrument Panel Cluster																																					V	V																	
S	2008	Colorado	Body	Passenger Presence System																																																						
S	2008	Colorado	Body	Base Radio																																																						
S	2008	Colorado	Body	Uplevel Radio																																																						
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																					V																		V
S	2008	Colorado	Body	Theft Deterrent Module																																					V																		
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																																						
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																											V	V	V	V																									
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V																																			
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V																																			
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																									
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V																																			
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																						
S	2008	TrailBlazer	Body	Body Control Module																																					V	V	V																
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																						
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																						
S	2008	TrailBlazer	Body	Driver Door Module																																					V	V	V																
S	2008	TrailBlazer	Body	Driver Seat Module																																																						
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																						
S	2008	TrailBlazer	Body	HVAC Control Module Auto																																																						
S	2008	TrailBlazer	Body	HVAC Control Module Manual																																																						
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																																						
S	2008	TrailBlazer	Body	Lift Gate Module																																					V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2008	TrailBlazer	Body	Passenger Door Module																																					V	V	V																
S	2008	TrailBlazer	Body	Passenger Presence System																																																						
S	2008	TrailBlazer	Body	Uplevel Radio																																																						
S	2008	TrailBlazer	Body	Navigation Radio																																																						
S	2008	TrailBlazer	Body	Rear Seat Audio																																																						
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																					V																		V
S	2008	TrailBlazer	Body	Theft Deterrent Module																																					V																		
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																						
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																									
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V											V																							
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																						
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																							
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																						
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																											V		V	V																									
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																V	V	V		V	V	V											V																							
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																						
S	2009	Colorado	Chassis	Electronic Brake Control Module																																			V																				
S	2009	Colorado	Body	Body Control Module																																					V	V	V																
S	2009	Colorado	Body	Digital Radio Receiver																																																						
S	2009	Colorado	Body	Generator Battery Control Module																																																						
S	2009	Colorado	Body	Instrument Panel Cluster																																					V	V																	
S	2009	Colorado	Body	Passenger Presence System																																																						
S	2009	Colorado	Body	Base Radio																																																						
S	2009	Colorado	Body	Uplevel Radio																																																						
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																					V																		V
S	2009	Colorado	Body	Theft Deterrent Module																																					V																		
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																											V	V	V	V																									
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V											V																							
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																						
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V	V	V											V																							
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																						
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																									
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V	V	V											V																							
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																						
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																						
S	2009	TrailBlazer	Body	Body Control Module																																					V	V	V																
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																						
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																						
S	2009	TrailBlazer	Body	Driver Door Module																																					V	V	V																
S	2009	TrailBlazer	Body	Driver Seat Module																																																						
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																						
S	2009	TrailBlazer	Body	HVAC Control Module Auto																																																						
S	2009	TrailBlazer	Body	HVAC Control Module Manual																																																						
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																																						
S	2009	TrailBlazer	Body	Lift Gate Module																																					V																		
S	2009	TrailBlazer	Body	Passenger Door Module																																					V	V	V																
S	2009	TrailBlazer	Body	Passenger Presence System																																																						
S	2009	TrailBlazer	Body	Uplevel Radio																																																						
S	2009	TrailBlazer	Body	Navigation Radio																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2009	TrailBlazer	Body	Rear Seat Audio																																																							
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																					V																			V
S	2009	TrailBlazer	Body	Theft Deterrent Module																																					V																		
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																									
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V											V																							
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																							
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																							
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																							
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																											V		V	V																									
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																V	V	V		V	V	V											V																							
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																							
S	2010	ALL	Chassis	Electronic Brake Control Module																																			V																				
S	2010	ALL	Body	Body Control Module																																					V	V	V																
S	2010	ALL	Body	Digital Radio Receiver																																																						
S	2010	ALL	Body	Generator Battery Control Module																																																						
S	2010	ALL	Body	Instrument Panel Cluster																																					V	V																	
S	2010	ALL	Body	Passenger Presence System																																																						
S	2010	ALL	Body	Personal Audio Link Module																																																						
S	2010	ALL	Body	Base Radio																																																						
S	2010	ALL	Body	Uplevel Radio																																																						
S	2010	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
S	2010	ALL	Body	Theft Deterrent Module																																					V																		
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																						
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																									
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V											V																							
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																						
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																							
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																						
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																											V		V	V																									
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																V	V	V		V	V	V											V																							
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																						
S	2011	ALL	Chassis	Electronic Brake Control Module																																			V																				
S	2011	ALL	Body	Body Control Module																																					V	V	V																
S	2011	ALL	Body	Digital Radio Receiver																																																						
S	2011	ALL	Body	Generator Battery Control Module																																																						
S	2011	ALL	Body	Instrument Panel Cluster																																					V	V																	
S	2011	ALL	Body	Passenger Presence System																																																						
S	2011	ALL	Body	Personal Audio Link Module																																																						
S	2011	ALL	Body	Base Radio																																																						
S	2011	ALL	Body	Uplevel Radio																																																						
S	2011	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
S	2011	ALL	Body	Theft Deterrent Module																																					V																		
S	2011	ALL	Body	Vehicle Comm. Interface Module																																																						
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																									
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V											V																							
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																						
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																							
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																											V		V	V																									
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																V	V	V		V	V	V										V																						
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																					
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																		V																				
S	2012	Colorado (First Gen)	Body	Body Control Module																																				V	V	V																
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																					
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																					
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																				V	V																	
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																					
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																					
S	2012	Colorado (First Gen)	Body	Base Radio																																																					
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																					
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																				V																		V
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																				V																		
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																					
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																					
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																					
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																					
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																					
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																					
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																					
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																					
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																					
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																					
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																					
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																					
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																					
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																					
S	2012	Colorado (Second Gen)	Body	Body Control Module																																																					
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																					
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																					
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																					
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																					
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																					
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																					
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																					
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																					
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																					
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																					
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																					
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																					
S	2012	S10	Powertrain	Transfer Case Control Module																																																					
S	2012	S10	Chassis	Electronic Brake Control Module																																																					
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																					
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																					
S	2012	S10	Body	Body Control Module																																																					
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																					
S	2012	S10	Body	Instrument Cluster																																																					
S	2012	S10	Body	Trailer Interface Control Module																																																					
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																					
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																					

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																									
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																										
S	2013	Colorado	Powertrain	Transfer Case Control Module																																																										
S	2013	Colorado	Chassis	Electronic Brake Control Module																																																										
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2013	Colorado	Body	Body Control Module																																																										
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Colorado	Body	Instrument Cluster																																																										
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2013	S10	Powertrain	Transfer Case Control Module																																																										
S	2013	S10	Chassis	Electronic Brake Control Module																																																										
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2013	S10	Body	Body Control Module																																																										
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	S10	Body	Instrument Cluster																																																										
S	2013	S10	Body	Trailer Interface Control Module																																																										
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																										
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																										
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																										
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2013	Trailblazer	Body	Body Control Module																																																										
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Trailblazer	Body	Instrument Cluster																																																										
S	2013	Trailblazer	Body	Trailer Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2013	Trailblazer	Body	Parking Assist Control Module																																																								
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																									
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																									
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																									
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2014	Colorado	Body	Body Control Module																																																									
S	2014	Colorado	Body	Body Control Module																																																									
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	Colorado	Body	Instrument Cluster																																																									
S	2014	Colorado	Body	Radio																																																									
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																									
S	2014	Colorado	Body	Parking Assist Control Module																																																									
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2014	S10	Powertrain	Transfer Case Control Module																																																									
S	2014	S10	Chassis	Electronic Brake Control Module																																																									
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2014	S10	Body	Body Control Module																																																									
S	2014	S10	Body	Body Control Module																																																									
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	S10	Body	Instrument Cluster																																																									
S	2014	S10	Body	Trailer Interface Control Module																																																									
S	2014	S10	Body	Radio																																																									
S	2014	S10	Body	Parking Assist Control Module																																																									
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																									
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																								
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2014	Trailblazer	Body	Body Control Module																																																								
S	2014	Trailblazer	Body	Body Control Module																																																								
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2014	Trailblazer	Body	Instrument Cluster																																																								
S	2014	Trailblazer	Body	Trailer Interface Control Module																																																								
S	2014	Trailblazer	Body	Parking Assist Control Module																																																								
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2015	Colorado	Powertrain	Chassis Control Module																																																								
S	2015	Colorado	Powertrain	Transfer Case Control Module																																																								
S	2015	Colorado	Chassis	Electronic Brake Control Module																																																								
S	2015	Colorado	Chassis	Power Steering Control Module																																																								
S	2015	Colorado	Body	Body Control Module																																																								
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2015	Colorado	Body	Passenger Presence Module																																																								
S	2015	Colorado	Body	Radio																																																								
S	2015	Colorado	Body	Amplifier																																																								
S	2015	Colorado	Body	Human Machine Interface Control Module																																																								
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																																								
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																								
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																								
S	2015	Colorado	Body	Frontview Camera Module																																																								
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																								
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																								
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2015	Colorado (MMM)	Body	Body Control Module																																																								
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2015	Colorado (MMM)	Body	Instrument Cluster																																																									
S	2015	Colorado (MMM)	Body	Radio																																																									
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																									
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																									
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2015	S10	Powertrain	Transfer Case Control Module																																																									
S	2015	S10	Chassis	Electronic Brake Control Module																																																									
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2015	S10	Body	Body Control Module																																																									
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2015	S10	Body	Instrument Cluster																																																									
S	2015	S10	Body	Trailer Interface Control Module																																																									
S	2015	S10	Body	Radio																																																									
S	2015	S10	Body	Telematics Communication Interface Control Module																																																									
S	2015	S10	Body	Parking Assist Control Module																																																									
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																									
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																									
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2015	Trailblazer	Body	Body Control Module																																																									
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2015	Trailblazer	Body	Instrument Cluster																																																									
S	2015	Trailblazer	Body	Trailer Interface Control Module																																																									
S	2015	Trailblazer	Body	Radio																																																									
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																									
S	2015	Trailblazer	Body	Parking Assist Control Module																																																									
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																									
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																									
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																										
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																										
S	2016	Colorado (1GC)	Body	Body Control Module																																																										
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																																										
S	2016	Colorado (1GC)	Body	Radio Controls																																																										
S	2016	Colorado (1GC)	Body	HVAC Controls																																																										
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																										
S	2016	Colorado (1GC)	Body	Radio																																																										
S	2016	Colorado (1GC)	Body	Amplifier																																																										
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																										
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																										
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																										
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																										
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																																										
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																										
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																										
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	Colorado (MMM)	Body	Body Control Module																																																										
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Colorado (MMM)	Body	Instrument Cluster																																																										
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																										
S	2016	Colorado (MMM)	Body	Radio																																																										
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																										
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																										
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																										
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																										
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	S10	Powertrain	Transfer Case Control Module																																																										
S	2016	S10	Chassis	Electronic Brake Control Module																																																										
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	S10	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2016	S10	Body	Instrument Cluster																																																									
S	2016	S10	Body	Trailer Interface Control Module																																																									
S	2016	S10	Body	Radio																																																									
S	2016	S10	Body	Telematics Communication Interface Control Module																																																									
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																									
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																									
S	2016	S10	Body	Parking Assist Control Module																																																									
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																									
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																									
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																									
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2016	Trailblazer	Body	Body Control Module																																																									
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2016	Trailblazer	Body	Instrument Cluster																																																									
S	2016	Trailblazer	Body	Trailer Interface Control Module																																																									
S	2016	Trailblazer	Body	Radio																																																									
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																									
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																									
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																									
S	2016	Trailblazer	Body	Parking Assist Control Module																																																									
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																											
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2004	S10	Chassis	4WAL 3 Sensor																																																									
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																									
T	2004	S10	Body	Body Control Module																																					V		V																		
T	2004	S10	Body	Instrument Panel Cluster																																					V	V	V																		
T	2004	S10	Body	Base Radio																																																									
T	2004	S10	Body	Uplevel Radio																																																									
T	2004	S10	Body	Supplemental Inflatable Restraint																																					V	V																			
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module													V	V	V																																									
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																V	V	V		V	V	V																																		
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module													V	V	V																																									
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																V	V	V		V	V	V																																		
T	2004	Colorado	Chassis	ABS Without Traction Control																																																									
T	2004	Colorado	Chassis	ABS With Traction Control																																																									
T	2004	Colorado	Body	Body Control Module																																					V	V	V																		
T	2004	Colorado	Body	Instrument Panel Cluster																																					V	V																		
T	2004	Colorado	Body	OnStar																																																								
T	2004	Colorado	Body	Base Radio																																																								
T	2004	Colorado	Body	Uplevel Radio																																																								
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																					V																			V
T	2004	Colorado	Body	Instrument Panel Cluster																																					V	V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																								
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																							
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																								
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																							
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																							
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																							
T	2004	TrailBlazer	Body	Body Control Module																																																							
T	2004	TrailBlazer	Body	Driver Door Module																																					V	V	V																	
T	2004	TrailBlazer	Body	Driver Seat Module																																																							
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																							
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																							
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																																							
T	2004	TrailBlazer	Body	Lift Gate Module																																																							
T	2004	TrailBlazer	Body	OnStar																																																							
T	2004	TrailBlazer	Body	Passenger Door Module																																					V	V	V																	
T	2004	TrailBlazer	Body	Uplevel Radio																																																							
T	2004	TrailBlazer	Body	Navigation Radio																																																							
T	2004	TrailBlazer	Body	Rear Seat Audio																																																							
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																							
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																					V	V																	
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																					V																	
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																								
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																							
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module													V	V																																									
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																V	V	V		V	V	V																																		
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																							
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																							
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																							
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																							
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																							
T	2004	TrailBlazer EXT	Body	Body Control Module																																																							
T	2004	TrailBlazer EXT	Body	Driver Door Module																																					V	V	V																	
T	2004	TrailBlazer EXT	Body	Driver Seat Module																																																							
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																							
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																							
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																							
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																							
T	2004	TrailBlazer EXT	Body	OnStar																																																							
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																					V	V	V																	
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																							
T	2004	TrailBlazer EXT	Body	Navigation Radio																																																							
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																							
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																							
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																							
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																					V	V																	
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																					V																	
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																									
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																							
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																							
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																							
T	2004	Blazer	Body	Body Control Module																																					V		V																
T	2004	Blazer	Body	Heating and Air Conditioning																																																							
T	2004	Blazer	Body	Instrument Panel Cluster																																					V	V	V																
T	2004	Blazer	Body	Memory Seat Module																																					V	V	V																
T	2004	Blazer	Body	Base Radio																																																							
T	2004	Blazer	Body	Uplevel Radio																																																							
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																					V	V																	
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module													V	V	V																																								
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																V	V	V		V	V	V																																	
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module													V	V	V																																								
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																V	V	V		V	V	V																																	
T	2005	Colorado	Chassis	ABS Without Traction Control																																																							
T	2005	Colorado	Chassis	ABS With Traction Control																																																							
T	2005	Colorado	Body	Body Control Module																																					V	V	V																
T	2005	Colorado	Body	Instrument Panel Cluster																																					V	V																	
T	2005	Colorado	Body	Base Radio																																																							
T	2005	Colorado	Body	Uplevel Radio																																																							
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																					V																		V
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																																							
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																								
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																							
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable													V	V																																									
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																							
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																							
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																							
T	2005	TrailBlazer	Body	Body Control Module																																																							
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																							
T	2005	TrailBlazer	Body	Driver Door Module																																					V	V	V																
T	2005	TrailBlazer	Body	Driver Seat Module																																																							
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																							
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																							
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																																							
T	2005	TrailBlazer	Body	Lift Gate Module																																																							
T	2005	TrailBlazer	Body	Passenger Door Module																																					V	V	V																
T	2005	TrailBlazer	Body	Passenger Presence System																																																							
T	2005	TrailBlazer	Body	Uplevel Radio																																																							
T	2005	TrailBlazer	Body	Navigation Radio																																																							
T	2005	TrailBlazer	Body	Rear Seat Audio																																																							
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																					V																		V
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																							
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																					V																		
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																								
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																							
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																						
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																								
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																								
T	2005	TrailBlazer EXT	Body	Body Control Module																																																								
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																								
T	2005	TrailBlazer EXT	Body	Driver Door Module																																					V	V	V																	
T	2005	TrailBlazer EXT	Body	Driver Seat Module																																																								
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																								
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																								
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																								
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																								
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																					V	V	V																	
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																								
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																								
T	2005	TrailBlazer EXT	Body	Navigation Radio																																																								
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																								
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																								
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																								
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																					V																			V
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																								
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																					V																			
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module												V	V																																											
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module															V	V	V		V	V	V																																			
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																								
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																								
T	2005	Blazer	Body	Body Control Module																																					V		V																	
T	2005	Blazer	Body	Heating and Air Conditioning																																																								
T	2005	Blazer	Body	Instrument Panel Cluster																																					V	V	V																	
T	2005	Blazer	Body	Memory Seat Module																																					V	V	V																	
T	2005	Blazer	Body	Base Radio																																																								
T	2005	Blazer	Body	Uplevel Radio																																																								
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																					V	V																		
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module												V	V	V																																										
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module															V	V	V		V	V	V																																			
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module												V	V	V																																										
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module															V	V	V		V	V	V																																			
T	2006	Colorado	Chassis	ABS Without Traction Control																																																								
T	2006	Colorado	Chassis	ABS With Traction Control																																																								
T	2006	Colorado	Body	Body Control Module																																					V	V	V																	
T	2006	Colorado	Body	Instrument Panel Cluster																																					V	V																		
T	2006	Colorado	Body	Passenger Presence System																																																								
T	2006	Colorado	Body	Base Radio																																																								
T	2006	Colorado	Body	Uplevel Radio																																																								
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																					V																			V
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																																								
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module												V	V	V																																										
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module															V	V	V		V	V	V																																			
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module															V	V	V		V													V																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																										
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V												V																									
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																								
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																								
T	2006	TrailBlazer	Body	Body Control Module																																					V	V	V																	
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																								
T	2006	TrailBlazer	Body	Driver Door Module																																					V	V	V																	
T	2006	TrailBlazer	Body	Driver Seat Module																																																								
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																								
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																								
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																																								
T	2006	TrailBlazer	Body	Lift Gate Module																																																								
T	2006	TrailBlazer	Body	Passenger Door Module																																					V	V	V																	
T	2006	TrailBlazer	Body	Passenger Presence System																																																								
T	2006	TrailBlazer	Body	Uplevel Radio																																																								
T	2006	TrailBlazer	Body	Navigation Radio																																																								
T	2006	TrailBlazer	Body	Rear Seat Audio																																																								
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																					V																			V
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																					V																			
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V												V																									
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																								
T	2006	TrailBlazer EXT	Body	Body Control Module																																					V	V	V																	
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																								
T	2006	TrailBlazer EXT	Body	Driver Door Module																																					V	V	V																	
T	2006	TrailBlazer EXT	Body	Driver Seat Module																																																								
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																								
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																								
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																								
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																								
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																					V	V	V																	
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																								
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																								
T	2006	TrailBlazer EXT	Body	Navigation Radio																																																								
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																								
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																								
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																								
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																					V																			V
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																					V																			
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V		V	V																										
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V																																		
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V		V	V																										
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V																																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																							
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																							
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																							
T	2007	Colorado	Body	Body Control Module																																				V	V	V																	
T	2007	Colorado	Body	Digital Radio Receiver																																																						
T	2007	Colorado	Body	Generator Battery Control Module																																																						
T	2007	Colorado	Body	Instrument Panel Cluster																																				V	V																	
T	2007	Colorado	Body	Passenger Presence System																																																						
T	2007	Colorado	Body	Base Radio																																																						
T	2007	Colorado	Body	Uplevel Radio																																																						
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																				V																		V
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																																						
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																											V		V	V																									
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																						
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																											V		V	V																									
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																V	V	V		V	V	V																																	
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																						
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V																																			
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																						
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																									
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V																																			
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																						
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																						
T	2007	Trailblazer	Body	Body Control Module																																				V	V	V																	
T	2007	Trailblazer	Body	Digital Radio Receiver																																																						
T	2007	Trailblazer	Body	Disc Player and Video Display																																																						
T	2007	Trailblazer	Body	Driver Door Module																																				V	V	V																	
T	2007	Trailblazer	Body	Driver Seat Module																																																						
T	2007	Trailblazer	Body	Generator Battery Control Module																																																						
T	2007	Trailblazer	Body	HVAC Control Module Auto																																																						
T	2007	Trailblazer	Body	HVAC Control Module Manual																																																						
T	2007	Trailblazer	Body	Instrument Panel Cluster																																																						
T	2007	Trailblazer	Body	Lift Gate Module																																				V																		
T	2007	Trailblazer	Body	Passenger Door Module																																				V	V	V																	
T	2007	Trailblazer	Body	Passenger Presence System																																																						
T	2007	Trailblazer	Body	Uplevel Radio																																																						
T	2007	Trailblazer	Body	Navigation Radio																																																						
T	2007	Trailblazer	Body	Rear Seat Audio																																																						
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																				V																		V
T	2007	Trailblazer	Body	Theft Deterrent Module																																				V																		
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																						
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																									
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V																																			
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																						
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V																																			
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																						
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																						
T	2008	Colorado	Body	Body Control Module																																				V	V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2008	Colorado	Body	Digital Radio Receiver																																																							
T	2008	Colorado	Body	Generator Battery Control Module																																																							
T	2008	Colorado	Body	Instrument Panel Cluster																																					V	V																	
T	2008	Colorado	Body	Passenger Presence System																																																						
T	2008	Colorado	Body	Base Radio																																																						
T	2008	Colorado	Body	Uplevel Radio																																																						
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																					V																		V
T	2008	Colorado	Body	Theft Deterrent Module																																					V																		
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																																						
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																										V	V	V	V																										
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V																																			
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																						
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																										V		V	V																										
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V																																			
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																						
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																										V		V	V																										
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V																																			
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																						
T	2008	TrailBlazer	Body	Body Control Module																																					V	V	V																
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																						
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																						
T	2008	TrailBlazer	Body	Driver Door Module																																					V	V	V																
T	2008	TrailBlazer	Body	Driver Seat Module																																																						
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																						
T	2008	TrailBlazer	Body	HVAC Control Module Auto																																																						
T	2008	TrailBlazer	Body	HVAC Control Module Manual																																																						
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																																						
T	2008	TrailBlazer	Body	Lift Gate Module																																					V																		
T	2008	TrailBlazer	Body	Passenger Door Module																																					V	V	V																
T	2008	TrailBlazer	Body	Passenger Presence System																																																						
T	2008	TrailBlazer	Body	Uplevel Radio																																																						
T	2008	TrailBlazer	Body	Navigation Radio																																																						
T	2008	TrailBlazer	Body	Rear Seat Audio																																																						
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																					V																		V
T	2008	TrailBlazer	Body	Theft Deterrent Module																																					V																		
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																						
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																										V	V	V	V																										
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V											V																							
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																						
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																						
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																										V	V	V	V																										
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																							
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																						
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																						
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																										V		V	V																										
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																V	V	V		V	V	V											V																							
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																						
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																						
T	2009	Colorado	Chassis	Electronic Brake Control Module																																			V																		
T	2009	Colorado	Body	Body Control Module																																					V	V	V																
T	2009	Colorado	Body	Digital Radio Receiver																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2009	Colorado	Body	Generator Battery Control Module																																																							
T	2009	Colorado	Body	Instrument Panel Cluster																																					V	V																	
T	2009	Colorado	Body	Passenger Presence System																																																							
T	2009	Colorado	Body	Base Radio																																																							
T	2009	Colorado	Body	Uplevel Radio																																																							
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																					V																		V
T	2009	Colorado	Body	Theft Deterrent Module																																					V																		
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																											V	V	V	V																									
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V											V																						
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																							
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V	V	V											V																						
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																						
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																									
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V	V	V											V																						
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																							
T	2009	TrailBlazer	Body	Body Control Module																																					V	V	V																	
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																							
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																							
T	2009	TrailBlazer	Body	Driver Door Module																																					V	V	V																	
T	2009	TrailBlazer	Body	Driver Seat Module																																																							
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																							
T	2009	TrailBlazer	Body	HVAC Control Module Auto																																																							
T	2009	TrailBlazer	Body	HVAC Control Module Manual																																																							
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																																							
T	2009	TrailBlazer	Body	Lift Gate Module																																					V																		
T	2009	TrailBlazer	Body	Passenger Door Module																																					V	V	V																	
T	2009	TrailBlazer	Body	Passenger Presence System																																																							
T	2009	TrailBlazer	Body	Uplevel Radio																																																							
T	2009	TrailBlazer	Body	Navigation Radio																																																							
T	2009	TrailBlazer	Body	Rear Seat Audio																																																							
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																					V																		V
T	2009	TrailBlazer	Body	Theft Deterrent Module																																					V																		
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V											V																						
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																						
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																						
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																						
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																						
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																						
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																											V		V	V																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																V	V	V		V	V	V											V																						
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																						
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																						
T	2010	ALL	Chassis	Electronic Brake Control Module																																			V																			
T	2010	ALL	Body	Body Control Module																																					V	V	V																	
T	2010	ALL	Body	Digital Radio Receiver																																																							
T	2010	ALL	Body	Generator Battery Control Module																																																							
T	2010	ALL	Body	Instrument Panel Cluster																																					V	V																	
T	2010	ALL	Body	Passenger Presence System																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2010	ALL	Body	Personal Audio Link Module																																																							
T	2010	ALL	Body	Base Radio																																																							
T	2010	ALL	Body	Uplevel Radio																																																							
T	2010	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
T	2010	ALL	Body	Theft Deterrent Module																																					V																		
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																						
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																									
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V											V																						
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																						
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																						
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																						
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																						
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																						
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																											V		V	V																									
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																V	V	V		V	V	V											V																						
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																						
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																						
T	2011	ALL	Chassis	Electronic Brake Control Module																																			V																			
T	2011	ALL	Body	Body Control Module																																					V	V	V																
T	2011	ALL	Body	Digital Radio Receiver																																																						
T	2011	ALL	Body	Generator Battery Control Module																																																						
T	2011	ALL	Body	Instrument Panel Cluster																																					V	V																	
T	2011	ALL	Body	Passenger Presence System																																																						
T	2011	ALL	Body	Personal Audio Link Module																																																						
T	2011	ALL	Body	Base Radio																																																						
T	2011	ALL	Body	Uplevel Radio																																																						
T	2011	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
T	2011	ALL	Body	Theft Deterrent Module																																					V																		
T	2011	ALL	Body	Vehicle Comm. Interface Module																																																						
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																									
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V											V																						
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																						
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																						
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																						
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																						
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																						
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																											V		V	V																									
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																V	V	V		V	V	V											V																						
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																						
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																						
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																			V																			
T	2012	Colorado (First Gen)	Body	Body Control Module																																					V	V	V																
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																						
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																						
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																					V	V																	
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																						
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																						
T	2012	Colorado (First Gen)	Body	Base Radio																																																						
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																					V																			V
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																					V																			
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																								
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																								
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2012	Colorado (Second Gen)	Body	Body Control Module																																																								
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																								
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																								
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2012	S10	Powertrain	Transfer Case Control Module																																																								
T	2012	S10	Chassis	Electronic Brake Control Module																																																								
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2012	S10	Body	Body Control Module																																																								
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	S10	Body	Instrument Cluster																																																								
T	2012	S10	Body	Trailer Interface Control Module																																																								
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2013	Colorado	Powertrain	Transfer Case Control Module																																																								
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																								
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2013	Colorado	Body	Body Control Module																																																								
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2013	Colorado	Body	Instrument Cluster																																																								
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2013	S10	Powertrain	Transfer Case Control Module																																																								
T	2013	S10	Chassis	Electronic Brake Control Module																																																								
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2013	S10	Body	Body Control Module																																																								
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2013	S10	Body	Instrument Cluster																																																								
T	2013	S10	Body	Trailer Interface Control Module																																																								
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																								
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																								
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																								
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2013	Trailblazer	Body	Body Control Module																																																								
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2013	Trailblazer	Body	Instrument Cluster																																																								
T	2013	Trailblazer	Body	Trailer Interface Control Module																																																								
T	2013	Trailblazer	Body	Parking Assist Control Module																																																								
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																								
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																								
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2014	Colorado	Powertrain	Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																									
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	Colorado	Body	Body Control Module																																																										
T	2014	Colorado	Body	Body Control Module																																																										
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Colorado	Body	Instrument Cluster																																																										
T	2014	Colorado	Body	Radio																																																										
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																										
T	2014	Colorado	Body	Parking Assist Control Module																																																										
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2014	S10	Powertrain	Transfer Case Control Module																																																										
T	2014	S10	Chassis	Electronic Brake Control Module																																																										
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	S10	Body	Body Control Module																																																										
T	2014	S10	Body	Body Control Module																																																										
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	S10	Body	Instrument Cluster																																																										
T	2014	S10	Body	Trailer Interface Control Module																																																										
T	2014	S10	Body	Radio																																																										
T	2014	S10	Body	Parking Assist Control Module																																																										
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																										
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	Trailblazer	Body	Body Control Module																																																										
T	2014	Trailblazer	Body	Body Control Module																																																										
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Trailblazer	Body	Instrument Cluster																																																										
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																										
T	2014	Trailblazer	Body	Parking Assist Control Module																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2015	Colorado	Powertrain	Chassis Control Module																																																										
T	2015	Colorado	Powertrain	Transfer Case Control Module																																																										
T	2015	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2015	Colorado	Chassis	Power Steering Control Module																																																										
T	2015	Colorado	Body	Body Control Module																																																										
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Colorado	Body	Passenger Presence Module																																																										
T	2015	Colorado	Body	Radio																																																										
T	2015	Colorado	Body	Amplifier																																																										
T	2015	Colorado	Body	Human Machine Interface Control Module																																																										
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																																										
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																										
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																										
T	2015	Colorado	Body	Frontview Camera Module																																																										
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																										
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																										
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2015	Colorado (MMM)	Body	Body Control Module																																																										
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Colorado (MMM)	Body	Instrument Cluster																																																										
T	2015	Colorado (MMM)	Body	Radio																																																										
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																										
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2015	S10	Powertrain	Transfer Case Control Module																																																										
T	2015	S10	Chassis	Electronic Brake Control Module																																																										
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2015	S10	Body	Body Control Module																																																										
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	S10	Body	Instrument Cluster																																																										
T	2015	S10	Body	Trailer Interface Control Module																																																										
T	2015	S10	Body	Radio																																																										
T	2015	S10	Body	Telematics Communication Interface Control Module																																																										
T	2015	S10	Body	Parking Assist Control Module																																																										
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																										
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2015	Trailblazer	Body	Body Control Module																																																										
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Trailblazer	Body	Instrument Cluster																																																										
T	2015	Trailblazer	Body	Trailer Interface Control Module																																																										
T	2015	Trailblazer	Body	Radio																																																										
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																										
T	2015	Trailblazer	Body	Parking Assist Control Module																																																										
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																										
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																										
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																										
T	2016	Colorado (1GC)	Body	Body Control Module																																																										
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																																										
T	2016	Colorado (1GC)	Body	Radio Controls																																																										
T	2016	Colorado (1GC)	Body	HVAC Controls																																																										
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																										
T	2016	Colorado (1GC)	Body	Radio																																																										
T	2016	Colorado (1GC)	Body	Amplifier																																																										
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																									
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																									
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																									
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																									
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																									
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																									
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																									
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																									
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2016	Colorado (MMM)	Body	Body Control Module																																																									
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																									
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																									
T	2016	Colorado (MMM)	Body	Radio																																																									
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																									
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																									
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																									
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																									
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																									
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																									
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
T	2016	S10	Powertrain	Transfer Case Control Module																																																									
T	2016	S10	Chassis	Electronic Brake Control Module																																																									
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2016	S10	Body	Body Control Module																																																									
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2016	S10	Body	Instrument Cluster																																																									
T	2016	S10	Body	Trailer Interface Control Module																																																									
T	2016	S10	Body	Radio																																																									
T	2016	S10	Body	Telematics Communication Interface Control Module																																																									
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																									
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																									
T	2016	S10	Body	Parking Assist Control Module																																																									
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																								
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																								
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2016	Trailblazer	Body	Body Control Module																																																								
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2016	Trailblazer	Body	Instrument Cluster																																																								
T	2016	Trailblazer	Body	Trailer Interface Control Module																																																								
T	2016	Trailblazer	Body	Radio																																																								
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																								
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																								
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																								
T	2016	Trailblazer	Body	Parking Assist Control Module																																																								
V	2009	ALL	Powertrain	Engine Control Module																											V		V	V																										
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2009	ALL	Powertrain	Rear Drive System																																																								
V	2009	ALL	Powertrain	Transmission Control Module																																V																								
V	2009	ALL	Chassis	Electronic Brake Control Module																																			V																					
V	2009	ALL	Body	Body Control Module			V																																			V	V																
V	2009	ALL	Body	Digital Radio Receiver																																																								
V	2009	ALL	Body	Driver Door Switch																																					V	V	V																
V	2009	ALL	Body	Heated Seat Module																																																								
V	2009	ALL	Body	HVAC Control Module Auto																																						V		V																
V	2009	ALL	Body	HVAC Control Module Manual																																						V		V																
V	2009	ALL	Body	Instrument Panel Cluster																																																								
V	2009	ALL	Body	Lift Gate Module																																					V																		
V	2009	ALL	Body	Park Assist Module																																																								
V	2009	ALL	Body	Passenger Door Switch																																					V	V	V																
V	2009	ALL	Body	Passenger Presence System																																					V																		
V	2009	ALL	Body	Radio																																																								
V	2009	ALL	Body	Rear HVAC/RSA																																																								
V	2009	ALL	Body	Rollover Sensor																																																								
V	2009	ALL	Body	Supplemental Inflatable Restraint																																					V																		
V	2009	ALL	Body	Theft Deterrent Module																																																								
V	2010	ALL	Powertrain	Engine Control Module																											V	V	V	V																										
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2010	ALL	Powertrain	Rear Drive System																																																								
V	2010	ALL	Powertrain	Transmission Control Module																																V	V																						
V	2010	ALL	Chassis	Electronic Brake Control Module																																			V																					
V	2010	ALL	Body	Body Control Module			V																																			V	V																
V	2010	ALL	Body	Digital Radio Receiver																																																								
V	2010	ALL	Body	Driver Door Switch																																					V	V	V																
V	2010	ALL	Body	Heated Seat Module																																																								
V	2010	ALL	Body	HVAC Control Module Auto																																						V		V																
V	2010	ALL	Body	HVAC Control Module Manual																																						V		V																
V	2010	ALL	Body	Instrument Panel Cluster																																																								
V	2010	ALL	Body	Lift Gate Module																																					V																		
V	2010	ALL	Body	Park Assist Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
V	2010	ALL	Body	Passenger Door Switch																																					V	V	V																
V	2010	ALL	Body	Passenger Presence System																																					V																		
V	2010	ALL	Body	Radio																																																							
V	2010	ALL	Body	Rear HVAC/RSA																																																							
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																							
V	2010	ALL	Body	Theft Deterrent Module																																																							
V	2011	ALL	Powertrain	Engine Control Module																											V	V	V	V																											
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																							
V	2011	ALL	Powertrain	Rear Drive System																																																							
V	2011	ALL	Powertrain	Transmission Control Module																																	V	V																						
V	2011	ALL	Chassis	Electronic Brake Control Module																																			V																				
V	2011	ALL	Body	Body Control Module			V																																			V	V																	
V	2011	ALL	Body	Digital Radio Receiver																																																							
V	2011	ALL	Body	Driver Door Switch																																					V	V	V																	
V	2011	ALL	Body	Heated Seat Module																																																							
V	2011	ALL	Body	HVAC Control Module Auto																																						V		V																
V	2011	ALL	Body	HVAC Control Module Manual																																						V		V																
V	2011	ALL	Body	Instrument Panel Cluster																																																							
V	2011	ALL	Body	Lift Gate Module																																					V																			
V	2011	ALL	Body	Park Assist Module																																																							
V	2011	ALL	Body	Passenger Door Switch																																					V	V	V																	
V	2011	ALL	Body	Passenger Presence System																																					V																			
V	2011	ALL	Body	Radio																																																							
V	2011	ALL	Body	Rear HVAC/RSA																																																							
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																							
V	2011	ALL	Body	Theft Deterrent Module																																																							
V	2012	ALL	Powertrain	Engine Control Module																											V	V	V	V																											
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																							
V	2012	ALL	Powertrain	Rear Drive System																																																							
V	2012	ALL	Powertrain	Transmission Control Module																																	V	V																						
V	2012	ALL	Chassis	Electronic Brake Control Module																																			V																				
V	2012	ALL	Body	Body Control Module			V																																			V	V																	
V	2012	ALL	Body	Digital Radio Receiver																																																							
V	2012	ALL	Body	Driver Door Switch																																					V	V	V																	
V	2012	ALL	Body	Heated Seat Module																																																							
V	2012	ALL	Body	HVAC Control Module Auto																																						V		V																
V	2012	ALL	Body	HVAC Control Module Manual																																						V		V																
V	2012	ALL	Body	Instrument Panel Cluster																																																							
V	2012	ALL	Body	Lift Gate Module																																					V																			
V	2012	ALL	Body	Park Assist Module																																																							
V	2012	ALL	Body	Passenger Door Switch																																					V	V	V																	
V	2012	ALL	Body	Passenger Presence System																																					V																			
V	2012	ALL	Body	Radio																																																							
V	2012	ALL	Body	Rear HVAC/RSA																																																							
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																							
V	2012	ALL	Body	Theft Deterrent Module																																																							
V	2013	ALL	Powertrain	Engine Control Module																											V	V	V	V																											
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																							
V	2013	ALL	Powertrain	Rear Drive System																																																							
V	2013	ALL	Powertrain	Transmission Control Module																																	V	V																						
V	2013	ALL	Chassis	Electronic Brake Control Module																																			V																				

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
V	2013	ALL	Body	Body Control Module			V																																			V	V																
V	2013	ALL	Body	Digital Radio Receiver																																																							
V	2013	ALL	Body	Driver Door Switch																																				V	V	V																		
V	2013	ALL	Body	Heated Seat Module																																																							
V	2013	ALL	Body	HVAC Control Module Auto																																					V		V																	
V	2013	ALL	Body	HVAC Control Module Manual																																					V		V																	
V	2013	ALL	Body	Instrument Panel Cluster																																																							
V	2013	ALL	Body	Left Side Object Detection Module																																																							
V	2013	ALL	Body	Lift Gate Module																																				V																				
V	2013	ALL	Body	Park Assist Module																																																							
V	2013	ALL	Body	Passenger Door Switch																																				V	V	V																		
V	2013	ALL	Body	Passenger Presence System																																				V																				
V	2013	ALL	Body	Radio																																																							
V	2013	ALL	Body	Rear HVAC/RSA																																																							
V	2013	ALL	Body	Right Side Object Detection Module																																																							
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																							
V	2013	ALL	Body	Theft Deterrent Module																																																							
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																							
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																							
V	2014	Traverse	Powertrain	Chassis Control Module																																																							
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																							
V	2014	Traverse	Chassis	Electronic Brake Control Module																																																							
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																							
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																							
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
V	2014	Traverse	Body	Passenger Presence Module																																																							
V	2014	Traverse	Body	Instrument Cluster																																																							
V	2014	Traverse	Body	Radio																																																							
V	2014	Traverse	Body	Rear Audio Control Module																																																							
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																							
V	2014	Traverse	Body	Personal Audio Link Control Module																																																							
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																							
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																							
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																							
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																							
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																							
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																							
V	2014	Traverse	Body	Liftgate Control Module																																																							
V	2014	Traverse	Body	Seat Memory Control Module																																																							
V	2014	Traverse	Body	Front Seat Heating Control Module																																																							
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																							
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																							
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																							
V	2014	Traverse	Body	Parking Assist Control Module																																																							
V	2014	Traverse	Body	Frontview Camera Module																																																							
V	2014	Traverse	Body	Theft Deterrent Module																																																							
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																							
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																							
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																							
V	2015	Traverse	Chassis	Electronic Brake Control Module																																																							
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Traverse	Body	Passenger Presence Module																																																										
V	2015	Traverse	Body	Instrument Cluster																																																										
V	2015	Traverse	Body	Radio																																																										
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2015	Traverse	Body	Liftgate Control Module																																																										
V	2015	Traverse	Body	Seat Memory Control Module																																																										
V	2015	Traverse	Body	Front Seat Heating Control Module																																																										
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2015	Traverse	Body	Parking Assist Control Module																																																										
V	2015	Traverse	Body	Frontview Camera Module																																																										
V	2015	Traverse	Body	Theft Deterrent Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Traverse	Chassis	Electronic Brake Control Module																																																										
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Traverse	Body	Passenger Presence Module																																																										
V	2016	Traverse	Body	Instrument Cluster																																																										
V	2016	Traverse	Body	Radio																																																										
V	2016	Traverse	Body	Rear Audio Control Module																																																										
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2016	Traverse	Body	Personal Audio Link Control Module																																																										
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																										
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Liftgate Control Module																																																										
V	2016	Traverse	Body	Seat Memory Control Module																																																										
V	2016	Traverse	Body	Front Seat Heating Control Module																																																										
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2016	Traverse	Body	Parking Assist Control Module																																																										
V	2016	Traverse	Body	Frontview Camera Module																																																										
V	2016	Traverse	Body	Theft Deterrent Module																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2011	Orlando	Chassis	Parking Brake Control Module																																																										
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2011	Orlando	Chassis	Power Steering Control Module																																																										
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2011	Orlando	Body	Body Control Module																																																										
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2011	Orlando	Body	Instrument Cluster																																																										
A	2011	Orlando	Body	Trailer Interface Control Module																																																										
A	2011	Orlando	Body	Radio																																																										
A	2011	Orlando	Body	Multimedia Player Interface Module																																																										
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
A	2011	Orlando	Body	Keyless Entry Control Module																																																										
A	2011	Orlando	Body	Parking Assist Control Module																																																										
A	2011	Orlando	Body	Steering Column Lock Control Module																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																										
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2012	Orlando	Chassis	Parking Brake Control Module																																																										
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2012	Orlando	Chassis	Power Steering Control Module																																																										
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2012	Orlando	Body	Body Control Module																																																										
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2012	Orlando	Body	Instrument Cluster																																																										
A	2012	Orlando	Body	Trailer Interface Control Module																																																										
A	2012	Orlando	Body	Radio																																																										
A	2012	Orlando	Body	Multimedia Player Interface Module																																																										
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
A	2012	Orlando	Body	Keyless Entry Control Module																																																										
A	2012	Orlando	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2012	Orlando	Body	Steering Column Lock Control Module																																																									
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																										
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2013	Orlando	Chassis	Parking Brake Control Module																																																										
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Orlando	Chassis	Power Steering Control Module																																																										
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	Orlando	Body	Body Control Module																																																										
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	Orlando	Body	Instrument Cluster																																																										
A	2013	Orlando	Body	Radio																																																										
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2013	Orlando	Body	Multimedia Player Interface Module																																																										
A	2013	Orlando	Body	Mobile Telephone Control Module																																																										
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2013	Orlando	Body	Front Seat Heating Control Module																																																										
A	2013	Orlando	Body	Keyless Entry Control Module																																																										
A	2013	Orlando	Body	Parking Assist Control Module																																																										
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																									
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																									
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2014	Orlando	Chassis	Power Steering Control Module																																																									
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2014	Orlando	Body	Body Control Module																																																									
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2014	Orlando	Body	Instrument Cluster																																																									
A	2014	Orlando	Body	Radio																																																									
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																									
A	2014	Orlando	Body	Multimedia Player Interface Module																																																									
A	2014	Orlando	Body	Mobile Telephone Control Module																																																									
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
A	2014	Orlando	Body	Front Seat Heating Control Module																																																									
A	2014	Orlando	Body	Rear Seat Heating Control Module																																																									
A	2014	Orlando	Body	Keyless Entry Control Module																																																									
A	2014	Orlando	Body	Parking Assist Control Module																																																									
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																									
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																									
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																									
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																									
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2015	Orlando	Chassis	Power Steering Control Module																																																									
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2015	Orlando	Body	Body Control Module																																																								
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2015	Orlando	Body	Instrument Cluster																																																								
A	2015	Orlando	Body	Radio																																																								
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																								
A	2015	Orlando	Body	Mobile Telephone Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																									
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
A	2015	Orlando	Body	Front Seat Heating Control Module																																																									
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																									
A	2015	Orlando	Body	Keyless Entry Control Module																																																									
A	2015	Orlando	Body	Parking Assist Control Module																																																									
A	2015	Orlando	Body	Frontview Camera Module																																																									
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																									
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																									
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																									
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																									
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																									
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																									
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2016	Orlando	Chassis	Power Steering Control Module																																																									
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2016	Orlando	Body	Body Control Module																																																								
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2016	Orlando	Body	Instrument Cluster																																																								
A	2016	Orlando	Body	Radio																																																								
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																									
A	2016	Orlando	Body	Multimedia Player Interface Module																																																									
A	2016	Orlando	Body	Mobile Telephone Control Module																																																									
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																									
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
A	2016	Orlando	Body	Front Seat Heating Control Module																																																									
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																									
A	2016	Orlando	Body	Keyless Entry Control Module																																																									
A	2016	Orlando	Body	Parking Assist Control Module																																																									
A	2016	Orlando	Body	Frontview Camera Module																																																									
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																																																									
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																																																									
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																																																									
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																																																											
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																																																											
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module													V	V	V																																												
C	2009	N200	Chassis	Electronic Brake Control Module																																																												
C	2009	N200	Body	Supplemental Inflatable Restraint																																																												
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module													V	V	V																																												
C	2009	N300	Chassis	Electronic Brake Control Module																																																												
C	2009	N300	Body	Supplemental Inflatable Restraint																																																												
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module													V	V	V																																												
C	2010	N200	Chassis	Electronic Brake Control Module																																																												
C	2010	N200	Body	Supplemental Inflatable Restraint																																																												
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module													V	V	V																																												
C	2010	N300	Chassis	Electronic Brake Control Module																																																												
C	2010	N300	Body	Supplemental Inflatable Restraint																																																												
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module													V	V	V																																												
C	2011	N200	Chassis	Electronic Brake Control Module																																																												
C	2011	N200	Body	Supplemental Inflatable Restraint																																																												
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module													V	V	V																																												
C	2011	N300	Chassis	Electronic Brake Control Module																																																												
C	2011	N300	Body	Supplemental Inflatable Restraint																																																												
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module													V	V	V																																												
C	2012	N200	Chassis	Electronic Brake Control Module																																																												
C	2012	N200	Body	Supplemental Inflatable Restraint																																																												
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module													V	V	V																																												
C	2012	N300	Chassis	Electronic Brake Control Module																																																												
C	2012	N300	Body	Supplemental Inflatable Restraint																																																												
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2013	N300	Chassis	Electronic Brake Control Module																																																												
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																																												
C	2014	N300	Chassis	Electronic Brake Control Module																																																												
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																																												
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																																												
C	2015	Max	Chassis	Electronic Brake Control Module																																																												
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																																												
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																																												
C	2015	Move	Chassis	Electronic Brake Control Module																																																												
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																																												
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																																												
C	2015	N300	Chassis	Electronic Brake Control Module																																																												
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																																										
C	2016	Max	Chassis	Electronic Brake Control Module																																																										
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																																										
C	2016	Move	Chassis	Electronic Brake Control Module																																																										
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																																										
C	2016	N300	Chassis	Electronic Brake Control Module																																																										
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																										
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																										
M	2015	City Express	Chassis	Electronic Brake Control Module																																																										
M	2015	City Express	Chassis	Power Steering Control Module																																																										
M	2015	City Express	Body	Body Control Module																																																										
M	2015	City Express	Body	Underhood Fuse Block																																																										
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	City Express	Body	Instrument Cluster																																																										
M	2015	City Express	Body	Tire Pressure Indicator Module																																																										
M	2015	City Express	Body	Radio																																																										
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																										
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																										
M	2016	City Express	Chassis	Electronic Brake Control Module																																																										
M	2016	City Express	Chassis	Power Steering Control Module																																																										
M	2016	City Express	Body	Body Control Module																																																									
M	2016	City Express	Body	Underhood Fuse Block																																																										
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	City Express	Body	Instrument Cluster																																																										
M	2016	City Express	Body	Tire Pressure Indicator Module																																																										
M	2016	City Express	Body	Radio																																																										
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2011	Orlando	Chassis	Parking Brake Control Module																																																										
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2011	Orlando	Chassis	Power Steering Control Module																																																										
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
P	2011	Orlando	Body	Body Control Module																																																								
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2011	Orlando	Body	Instrument Cluster																																																								
P	2011	Orlando	Body	Trailer Interface Control Module																																																								
P	2011	Orlando	Body	Radio																																																								
P	2011	Orlando	Body	Multimedia Player Interface Module																																																								
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																								
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																								
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																								
P	2011	Orlando	Body	Keyless Entry Control Module																																																								
P	2011	Orlando	Body	Parking Assist Control Module																																																								
P	2011	Orlando	Body	Steering Column Lock Control Module																																																								
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																								
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																								
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																								
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																								
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																																								
P	2012	Orlando	Chassis	Electronic Brake Control Module																																																								
P	2012	Orlando	Chassis	Parking Brake Control Module																																																								
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2012	Orlando	Chassis	Power Steering Control Module																																																								
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2012	Orlando	Body	Body Control Module																																																								
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2012	Orlando	Body	Instrument Cluster																																																								
P	2012	Orlando	Body	Trailer Interface Control Module																																																								
P	2012	Orlando	Body	Radio																																																								
P	2012	Orlando	Body	Multimedia Player Interface Module																																																								
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																								
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																								
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																								
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																								
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																								
P	2012	Orlando	Body	Keyless Entry Control Module																																																								
P	2012	Orlando	Body	Parking Assist Control Module																																																								
P	2012	Orlando	Body	Steering Column Lock Control Module																																																								
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																									
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																									
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2013	Orlando	Chassis	Parking Brake Control Module																																																									
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2013	Orlando	Chassis	Power Steering Control Module																																																									
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2013	Orlando	Body	Body Control Module																																																									
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2013	Orlando	Body	Instrument Cluster																																																									
P	2013	Orlando	Body	Radio																																																									
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																									
P	2013	Orlando	Body	Multimedia Player Interface Module																																																									
P	2013	Orlando	Body	Mobile Telephone Control Module																																																									
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
P	2013	Orlando	Body	Front Seat Heating Control Module																																																									
P	2013	Orlando	Body	Keyless Entry Control Module																																																									
P	2013	Orlando	Body	Parking Assist Control Module																																																									
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																									
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
P	2014	Orlando	Chassis	Power Steering Control Module																																																									
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2014	Orlando	Body	Body Control Module																																																									
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2014	Orlando	Body	Instrument Cluster																																																									
P	2014	Orlando	Body	Radio																																																									
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																									
P	2014	Orlando	Body	Multimedia Player Interface Module																																																									
P	2014	Orlando	Body	Mobile Telephone Control Module																																																									
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
P	2014	Orlando	Body	Front Seat Heating Control Module																																																									
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																									
P	2014	Orlando	Body	Keyless Entry Control Module																																																									
P	2014	Orlando	Body	Parking Assist Control Module																																																									
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																									
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																									
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																									
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2015	Orlando	Chassis	Power Steering Control Module																																																									
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2015	Orlando	Body	Body Control Module																																																									
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2015	Orlando	Body	Instrument Cluster																																																									
P	2015	Orlando	Body	Radio																																																									
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																									
P	2015	Orlando	Body	Mobile Telephone Control Module																																																									
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																									
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
P	2015	Orlando	Body	Front Seat Heating Control Module																																																									
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																									
P	2015	Orlando	Body	Keyless Entry Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
P	2015	Orlando	Body	Parking Assist Control Module																																																								
P	2015	Orlando	Body	Frontview Camera Module																																																								
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																								
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																								
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																								
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																								
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																								
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																								
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2016	Orlando	Chassis	Power Steering Control Module																																																								
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2016	Orlando	Body	Body Control Module																																																								
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2016	Orlando	Body	Instrument Cluster																																																								
P	2016	Orlando	Body	Radio																																																								
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																								
P	2016	Orlando	Body	Multimedia Player Interface Module																																																								
P	2016	Orlando	Body	Mobile Telephone Control Module																																																								
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																																								
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																								
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																								
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																								
P	2016	Orlando	Body	Front Seat Heating Control Module																																																								
P	2016	Orlando	Body	Rear Seat Heating Control Module																																																								
P	2016	Orlando	Body	Keyless Entry Control Module																																																								
P	2016	Orlando	Body	Parking Assist Control Module																																																								
P	2016	Orlando	Body	Frontview Camera Module																																																								
U	2004	ALL	Powertrain	Engine Control Module													V	V																																										
U	2004	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V																															
U	2004	ALL	Body	Digital Radio Receiver																																																								
U	2004	ALL	Body	Driver Information Center																																																								
U	2004	ALL	Body	Instrument Panel Cluster																																					V	V								V	V									
U	2004	ALL	Body	Radio																																																V							V
U	2004	ALL	Body	Supplemental Inflatable Restraint																																					V																			
U	2004	ALL	Body	Vehicle Theft Deterrent																																					V	V										V								
U	2005	ALL	Powertrain	Engine Control Module																																																								
U	2005	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V																							
U	2005	ALL	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
U	2005	ALL	Body	Body Control Module																																						V	V	V															
U	2005	ALL	Body	Disc Player and Video																																																						
U	2005	ALL	Body	Digital Radio Receiver																																																						
U	2005	ALL	Body	HVAC Control Module																																								V			V												
U	2005	ALL	Body	Instrument Panel Cluster																																																						
U	2005	ALL	Body	Left Power Sliding Door Module																																																						
U	2005	ALL	Body	Mobile Digital Media																																																						
U	2005	ALL	Body	Navigation Radio																																																						
U	2005	ALL	Body	Navigation Radio																																																						
U	2005	ALL	Body	Radio																																																						
U	2005	ALL	Body	Right Power Sliding Door Module																																																						
U	2005	ALL	Body	Supplemental Inflatable Restraint																																						V																	
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																						
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																V	V	V		V	V	V	V		V								V																						
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																						
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																V	V	V		V	V	V	V		V								V																						
U	2006	ALL	Chassis	Electronic Brake Control Module																																																						
U	2006	ALL	Body	Body Control Module																																						V	V	V															
U	2006	ALL	Body	Disc Player and Video																																																						
U	2006	ALL	Body	Digital Radio Receiver																																																						
U	2006	ALL	Body	HVAC Control Module																																								V			V												
U	2006	ALL	Body	Instrument Panel Cluster																																																						
U	2006	ALL	Body	Left Power Sliding Door Module																																																						
U	2006	ALL	Body	Mobile Digital Media																																																						
U	2006	ALL	Body	Navigation Radio																																																						
U	2006	ALL	Body	Navigation Radio																																																						
U	2006	ALL	Body	Radio																																																						
U	2006	ALL	Body	Right Power Sliding Door Module																																																						
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																											V		V	V																									
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																V	V	V		V	V	V	V		V								V																						
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																											V		V	V																									
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																V	V	V		V	V	V	V		V								V																						
U	2007	ALL	Chassis	Electronic Brake Control Module																																																						
U	2007	ALL	Body	Body Control Module																																						V	V	V															
U	2007	ALL	Body	Digital Radio Receiver																																																						
U	2007	ALL	Body	Disc Player and Video Display																																																						
U	2007	ALL	Body	HVAC Control Module																																								V			V												
U	2007	ALL	Body	Left Power Sliding Door Module																																																						
U	2007	ALL	Body	Mobile Digital Media																																																						
U	2007	ALL	Body	Radio																																																						
U	2007	ALL	Body	Navigation Radio																																																						
U	2007	ALL	Body	Right Power Sliding Door Module																																																						
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																											V		V	V																									
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																V	V	V		V	V	V	V		V								V																						
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																											V		V	V																									
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																V	V	V		V	V	V	V		V								V																						
U	2008	ALL	Chassis	Electronic Brake Control Module																																																						
U	2008	ALL	Body	Body Control Module																																						V	V	V															
U	2008	ALL	Body	Digital Radio Receiver																																																						
U	2008	ALL	Body	Disc Player and Video Display																																																						
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																								V			V												

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																								V			V													
U	2008	ALL	Body	Left Power Sliding Door Module																																																							
U	2008	ALL	Body	Radio																																																							
U	2008	ALL	Body	Navigation Radio																																																							
U	2008	ALL	Body	Remote Control Door Lock Receiver																																																							
U	2008	ALL	Body	Right Power Sliding Door Module																																																							
U	2009	ALL	Powertrain	Engine Control Module																											V		V	V																										
U	2009	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V																							
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																			V																				
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																							
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																							
U	2009	ALL	Body	Body Control Module																																					V	V	V																	
U	2009	ALL	Body	Digital Radio Receiver																																																							
U	2009	ALL	Body	Disc Player and Video Display																																																							
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																								V			V													
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																								V			V													
U	2009	ALL	Body	Instrument Panel Cluster																																																							
U	2009	ALL	Body	Left Power Sliding Door Module																																																							
U	2009	ALL	Body	Radio																																																							
U	2009	ALL	Body	Remote Control Door Lock Receiver																																																							
U	2009	ALL	Body	Right Power Sliding Door Module																																																							
V	2004	ALL	Powertrain	Engine Data Display													V	V																																									
V	2004	ALL	Powertrain	Transmission Data Display																V	V	V		V	V	V	V		V																															
V	2004	ALL	Body	Digital Radio Receiver																																																							
V	2004	ALL	Body	Driver Information Center																																																							
V	2004	ALL	Body	Instrument Panel Cluster																																					V	V									V	V							
V	2004	ALL	Body	Radio																																															V							V
V	2004	ALL	Body	Supplemental Inflatable Restraint																																					V																		
V	2004	ALL	Body	Vehicle Theft Deterrent																																					V	V										V							
V	2005	Venture	Powertrain	Engine Control Module													V	V																																									
V	2005	Venture	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V																															
V	2005	Venture	Body	Digital Radio Receiver																																																							
V	2005	Venture	Body	Driver Information Center																																																							
V	2005	Venture	Body	Instrument Panel Cluster																																					V	V									V	V							
V	2005	Venture	Body	Radio																																															V							V
V	2005	Venture	Body	Supplemental Inflatable Restraint																																					V																		
V	2005	Venture	Body	Vehicle Theft Deterrent																																					V	V										V							
V	2005	Uplander	Powertrain	Engine Control Module																																																							
V	2005	Uplander	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V																							
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																							
V	2005	Uplander	Body	Body Control Module																																					V	V	V																	
V	2005	Uplander	Body	Disc Player and Video																																																							
V	2005	Uplander	Body	Digital Radio Receiver																																																							
V	2005	Uplander	Body	HVAC Control Module																																								V			V													
V	2005	Uplander	Body	Instrument Panel Cluster																																																							
V	2005	Uplander	Body	Left Power Sliding Door Module																																																							
V	2005	Uplander	Body	Mobile Digital Media																																																							
V	2005	Uplander	Body	Navigation Radio																																																							
V	2005	Uplander	Body	Navigation Radio																																																							
V	2005	Uplander	Body	Radio																																																							
V	2005	Uplander	Body	Right Power Sliding Door Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
V	2005	Uplander	Body	Supplemental Inflatable Restraint																																					V																			
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																									
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																V	V	V		V	V	V	V		V								V																								
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																									
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																V	V	V		V	V	V	V		V								V																								
V	2006	ALL	Chassis	Electronic Brake Control Module																																																								
V	2006	ALL	Body	Body Control Module																																					V	V	V																		
V	2006	ALL	Body	Disc Player and Video																																																								
V	2006	ALL	Body	Digital Radio Receiver																																																								
V	2006	ALL	Body	HVAC Control Module																																								V			V														
V	2006	ALL	Body	Instrument Panel Cluster																																																								
V	2006	ALL	Body	Left Power Sliding Door Module																																																								
V	2006	ALL	Body	Mobile Digital Media																																																								
V	2006	ALL	Body	Navigation Radio																																																								
V	2006	ALL	Body	Navigation Radio																																																								
V	2006	ALL	Body	Radio																																																								
V	2006	ALL	Body	Right Power Sliding Door Module																																																								
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																											V		V	V																											
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																V	V	V		V	V	V	V		V								V																								
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																											V		V	V																											
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																V	V	V		V	V	V	V		V								V																								
V	2007	ALL	Chassis	Electronic Brake Control Module																																																								
V	2007	ALL	Body	Body Control Module																																					V	V	V																		
V	2007	ALL	Body	Digital Radio Receiver																																																								
V	2007	ALL	Body	Disc Player and Video Display																																																								
V	2007	ALL	Body	HVAC Control Module																																								V			V														
V	2007	ALL	Body	Left Power Sliding Door Module																																																								
V	2007	ALL	Body	Mobile Digital Media																																																								
V	2007	ALL	Body	Radio																																																								
V	2007	ALL	Body	Navigation Radio																																																								
V	2007	ALL	Body	Right Power Sliding Door Module																																																								
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																											V		V	V																											
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																V	V	V		V	V	V	V		V								V																								
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																											V		V	V																											
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																V	V	V		V	V	V	V		V								V																								
V	2008	ALL	Chassis	Electronic Brake Control Module																																																								
V	2008	ALL	Body	Body Control Module																																					V	V	V																		
V	2008	ALL	Body	Digital Radio Receiver																																																								
V	2008	ALL	Body	Disc Player and Video Display																																																								
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																								V			V														
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																								V			V														
V	2008	ALL	Body	Left Power Sliding Door Module																																																								
V	2008	ALL	Body	Radio																																																								
V	2008	ALL	Body	Navigation Radio																																																								
V	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
V	2008	ALL	Body	Right Power Sliding Door Module																																																								
V	2009	ALL	Powertrain	Engine Control Module																											V		V	V																											
V	2009	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V																								
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																			V																						
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																								
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
V	2009	ALL	Body	Body Control Module																																						V	V	V																
V	2009	ALL	Body	Digital Radio Receiver																																																								
V	2009	ALL	Body	Disc Player and Video Display																																																								
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																								V			V														
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																								V			V														
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																								
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																								
V	2009	ALL	Body	Left Power Sliding Door Module																																																								
V	2009	ALL	Body	Radio																																																								
V	2009	ALL	Body	Remote Control Door Lock Receiver																																																								
V	2009	ALL	Body	Right Power Sliding Door Module																																																								
X	2004	ALL	Powertrain	Engine Control Module													V	V																																										
X	2004	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V																																
X	2004	ALL	Body	Digital Radio Receiver																																																								
X	2004	ALL	Body	Driver Information Center																																																								
X	2004	ALL	Body	Instrument Panel Cluster																																						V	V									V	V							
X	2004	ALL	Body	Radio																																																V							V
X	2004	ALL	Body	Supplemental Inflatable Restraint																																						V																		
X	2004	ALL	Body	Vehicle Theft Deterrent																																						V	V										V							
X	2005	ALL	Powertrain	Engine Control Module																																																								
X	2005	ALL	Powertrain	Transmission Control Module																V	V	V		V	V	V	V		V								V																								
X	2005	ALL	Chassis	Electronic Brake Control Module																																																								
X	2005	ALL	Body	Body Control Module																																						V	V	V																	
X	2005	ALL	Body	Disc Player and Video																																																								
X	2005	ALL	Body	Digital Radio Receiver																																																								
X	2005	ALL	Body	HVAC Control Module																																								V			V														
X	2005	ALL	Body	Instrument Panel Cluster																																																								
X	2005	ALL	Body	Left Power Sliding Door Module																																																								
X	2005	ALL	Body	Mobile Digital Media																																																								
X	2005	ALL	Body	Navigation Radio																																																								
X	2005	ALL	Body	Navigation Radio																																																								
X	2005	ALL	Body	Radio																																																								
X	2005	ALL	Body	Right Power Sliding Door Module																																																								
X	2005	ALL	Body	Supplemental Inflatable Restraint																																						V																		
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																								
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																V	V	V		V	V	V	V		V								V																								
X	2006	ALL	Chassis	Electronic Brake Control Module																																																								
X	2006	ALL	Body	Body Control Module																																						V	V	V																	
X	2006	ALL	Body	Disc Player and Video																																																								
X	2006	ALL	Body	Digital Radio Receiver																																																								
X	2006	ALL	Body	HVAC Control Module																																								V			V														
X	2006	ALL	Body	Instrument Panel Cluster																																																								
X	2006	ALL	Body	Left Power Sliding Door Module																																																								
X	2006	ALL	Body	Mobile Digital Media																																																								
X	2006	ALL	Body	Navigation Radio																																																								
X	2006	ALL	Body	Navigation Radio																																																								
X	2006	ALL	Body	Radio																																																								
X	2006	ALL	Body	Right Power Sliding Door Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module			V		V																																																				
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module					V																																																				
A	2006	ALL	Powertrain	Transmission Control Module																																																									
A	2006	ALL	Chassis	Electronic Brake Control Module											V	V	V																																												
A	2006	ALL	Chassis	Power Steering Control Module																																																										
A	2006	ALL	Body	Body Control Module			V																																			V																			
A	2006	ALL	Body	Digital Radio Receiver																																																									
A	2006	ALL	Body	Instrument Panel Cluster																																																									
A	2006	ALL	Body	Radio																																																									
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2006	ALL	Body	Theft Deterrent Module		V																																																							
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module					V																																																	V		
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																									
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module					V																																																				
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																									
A	2007	ALL	Chassis	Electronic Brake Control Module											V	V	V																																												
A	2007	ALL	Chassis	Power Steering Control Module																																																										
A	2007	ALL	Body	Body Control Module			V																																			V																			
A	2007	ALL	Body	Digital Radio Receiver																																																									
A	2007	ALL	Body	Instrument Panel Cluster																																																									
A	2007	ALL	Body	Radio																																																									
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2007	ALL	Body	Theft Deterrent Module		V																																																							
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module					V																																																	V		
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																									
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module					V																																																	V		
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																									
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module					V																																																				
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																									
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES											V	V	V																																												
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES											V	V	V																																												
A	2008	HHR	Chassis	Power Steering Control Module																																																									
A	2008	HHR	Chassis	Power Steering Control Module																																																									
A	2008	HHR	Body	Body Control Module			V																																V			V																			
A	2008	HHR	Body	Digital Radio Receiver																																																									
A	2008	HHR	Body	Instrument Panel Cluster																																																									
A	2008	HHR	Body	Radio																																																									
A	2008	HHR	Body	Supplemental Inflatable Restraint																																																									
A	2008	HHR	Body	Theft Deterrent Module		V																																																							
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module					V																																																	V		
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																									
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module					V																																																	V		
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																									
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module					V																																																				
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																									
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES											V	V	V																																												
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES											V	V	V																																												
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																									
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																									
A	2008	HHR Panel	Body	Body Control Module			V																																V			V																			
A	2008	HHR Panel	Body	Digital Radio Receiver																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																								
A	2008	HHR Panel	Body	Radio																																																								
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																																								
A	2008	HHR Panel	Body	Theft Deterrent Module		V																																																						
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																																								
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																																								
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module					V																																															V		
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																							
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module					V																																													V			V
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																						
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module					V																																													V			V
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																						
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES											V	V	V																																									
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES											V	V	V																																									
A	2009	HHR	Chassis	Power Steering Control Module																																																						
A	2009	HHR	Chassis	Power Steering Control Module																																																						
A	2009	HHR	Body	Body Control Module			V																																V			V																	
A	2009	HHR	Body	Digital Radio Receiver																																																						
A	2009	HHR	Body	Instrument Panel Cluster																																																						
A	2009	HHR	Body	Radio																																																						
A	2009	HHR	Body	Supplemental Inflatable Restraint																																																						
A	2009	HHR	Body	Theft Deterrent Module		V																																																				
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module					V																																														V		
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																						
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module					V																																													V			V
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																						
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module					V																																													V			V
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																						
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES											V	V	V																																									
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES											V	V	V																																									
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																						
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																						
A	2009	HHR Panel	Body	Body Control Module			V																																V			V																	
A	2009	HHR Panel	Body	Digital Radio Receiver																																																						
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																						
A	2009	HHR Panel	Body	Radio																																																						
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																																						
A	2009	HHR Panel	Body	Theft Deterrent Module		V																																																				
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module					V																																														V		
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																						
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module					V																																													V			V
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																						
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module					V																																													V			V
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																						
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES											V	V	V																																									
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES											V	V	V																																									
A	2010	HHR	Chassis	Power Steering Control Module																																																						
A	2010	HHR	Chassis	Power Steering Control Module																																																						
A	2010	HHR	Body	Body Control Module			V																																V			V																	
A	2010	HHR	Body	Digital Radio Receiver																																																						
A	2010	HHR	Body	Instrument Panel Cluster																																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2010	HHR	Body	Radio																																																								
A	2010	HHR	Body	Supplemental Inflatable Restraint																																																								
A	2010	HHR	Body	Theft Deterrent Module		V																																																						
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module					V																																																V			
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																								
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module					V																																																V			V
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																								
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module					V																																																V			V
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																								
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES											V	V	V																																											
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES											V	V	V																																											
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																								
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																								
A	2010	HHR Panel	Body	Body Control Module			V																																V			V																		
A	2010	HHR Panel	Body	Digital Radio Receiver																																																								
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																								
A	2010	HHR Panel	Body	Radio																																																								
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																																								
A	2010	HHR Panel	Body	Theft Deterrent Module		V																																																						
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module					V																																																V			V
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																								
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module					V																																																V			V
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																								
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES											V	V	V																																											
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES											V	V	V																																											
A	2011	HHR	Chassis	Power Steering Control Module																																																								
A	2011	HHR	Body	Body Control Module			V																																V			V																		
A	2011	HHR	Body	Digital Radio Receiver																																																								
A	2011	HHR	Body	Instrument Panel Cluster																																																								
A	2011	HHR	Body	Radio																																																								
A	2011	HHR	Body	Supplemental Inflatable Restraint																																																								
A	2011	HHR	Body	Theft Deterrent Module		V																																																						
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module					V																																																V			V
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																								
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module					V																																																V			V
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																								
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES											V	V	V																																											
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES											V	V	V																																											
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																								
A	2011	HHR Panel	Body	Body Control Module			V																																V			V																		
A	2011	HHR Panel	Body	Digital Radio Receiver																																																								
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																								
A	2011	HHR Panel	Body	Radio																																																								
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																																								
A	2011	HHR Panel	Body	Theft Deterrent Module		V																																																						
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																									
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																									
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																							V		
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																									
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																									
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer					V																																																			
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer					V																																																			
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer					V																																																			
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer					V																																																			
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																									
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																									
A	2013	Trax	Chassis	Electronic Brake Control Module																																																									
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2013	Trax	Chassis	Power Steering Control Module																																																									
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2013	Trax	Body	Body Control Module																																																									
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2013	Trax	Body	Passenger Presence Module																																																									
A	2013	Trax	Body	Instrument Cluster																																																									
A	2013	Trax	Body	Radio																																																									
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																									
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																									
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																									
A	2013	Trax	Body	Front Seat Heating Control Module																																																									
A	2013	Trax	Body	Parking Assist Control Module																																																									
A	2013	Trax	Body	Frontview Camera Module																																																									
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																									
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																						V		
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																								
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer					V																																																			
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																								
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer					V																																																			
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																								
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																								
A	2014	Trax	Chassis	Electronic Brake Control Module																																																								
A	2014	Trax	Chassis	Power Steering Control Module																																																								
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2014	Trax	Body	Body Control Module																																																								
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2014	Trax	Body	Passenger Presence Module																																																								
A	2014	Trax	Body	Instrument Cluster																																																								
A	2014	Trax	Body	Radio																																																								
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
A	2014	Trax	Body	Front Seat Heating Control Module																																																								
A	2014	Trax	Body	Parking Assist Control Module																																																								
A	2014	Trax	Body	Frontview Camera Module																																																								
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																								
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																								
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																						V		
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																								
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission					V																																																			
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission					V																																																			
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																								
A	2015	Trax	Powertrain	Chassis Control Module																																																								
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																								
A	2015	Trax	Chassis	Electronic Brake Control Module																																																								
A	2015	Trax	Chassis	Power Steering Control Module																																																								
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2015	Trax	Body	Body Control Module																																																								
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2015	Trax	Body	Passenger Presence Module																																																								
A	2015	Trax	Body	Instrument Cluster																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2015	Trax	Body	Radio																																																									
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																									
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																									
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																									
A	2015	Trax	Body	Seat Memory Control Module																																																									
A	2015	Trax	Body	Front Seat Heating Control Module																																																									
A	2015	Trax	Body	Right Side Object Detection Control Module																																																									
A	2015	Trax	Body	Left Side Object Detection Control Module																																																									
A	2015	Trax	Body	Parking Assist Control Module																																																									
A	2015	Trax	Body	Frontview Camera Module																																																									
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																									
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																									
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																									
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																									
A	2016	Trax	Powertrain	Chassis Control Module																																																									
A	2016	Trax	Chassis	Electronic Brake Control Module																																																									
A	2016	Trax	Chassis	Power Steering Control Module																																																									
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2016	Trax	Body	Body Control Module																																																									
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2016	Trax	Body	Passenger Presence Module																																																									
A	2016	Trax	Body	Instrument Cluster																																																									
A	2016	Trax	Body	Trailer Interface Control Module																																																									
A	2016	Trax	Body	Radio																																																									
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																									
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																									
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																									
A	2016	Trax	Body	Seat Memory Control Module																																																									
A	2016	Trax	Body	Front Seat Heating Control Module																																																									
A	2016	Trax	Body	Right Side Object Detection Control Module																																																									
A	2016	Trax	Body	Left Side Object Detection Control Module																																																									
A	2016	Trax	Body	Parking Assist Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2016	Trax	Body	Frontview Camera Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM			V	V	V																																																					
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM			V	V	V																																																					
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM			V	V	V																																																					
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																					
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																					
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module			V	V	V																																																					
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module					V																																																					
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module				V	V																																																					
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module				V	V																																																					
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module					V																																																					
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module			V	V	V																																																					
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																			V																																							
C	2004	ALL	Body	Heating and Air Conditioning Auto																			V																																							
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																			V																																							
C	2004	ALL	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2004	ALL	Body	OnStar																																																V	V						
C	2004	ALL	Body	Passenger Door Module																																																							
C	2004	ALL	Body	Passenger Presence System																																																							
C	2004	ALL	Body	Radio Base																																																							
C	2004	ALL	Body	Radio Uplevel																																																							
C	2004	ALL	Body	Radio Navigation								V																																															
C	2004	ALL	Body	Rear Aux. Climate Module																																																							
C	2004	ALL	Body	Rear HVAC																																																							
C	2004	ALL	Body	Rear Seat Audio																																																							
C	2004	ALL	Body	Rear Seat Entertainment																																																							
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																							
C	2004	ALL	Body	Vehicle Theft Deterrent		V																																																						
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM			V	V	V																																																			
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																							
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																							
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																							
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																							
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM			V	V	V																																																			
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																							
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM			V	V	V																																																		
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																							
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																			
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																			
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module			V	V	V																																																			
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																			
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module			V	V	V																																																			
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module					V																																																			
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module				V	V																																																			
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module				V	V																																																			
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																			
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module			V	V	V																																																			
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																								
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																								
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																								
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																								
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
C	2005	ALL	Chassis	ESC																																																								
C	2005	ALL	Chassis	Rear Wheel Steering																																																								
C	2005	ALL	Chassis	Tire Pressure Monitor																																																								
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2005	ALL	Chassis	VSES																																																												
C	2005	ALL	Body	Amplifier (Bose)																																																												
C	2005	ALL	Body	Body Control Module																																																												
C	2005	ALL	Body	CD Changer																																																												
C	2005	ALL	Body	Chime																																																												
C	2005	ALL	Body	Disc Player and Video Display																																																												
C	2005	ALL	Body	Driver Door Module																																																												
C	2005	ALL	Body	Driver Seat Module																			V																																									
C	2005	ALL	Body	Generator Battery Control Module																																																												
C	2005	ALL	Body	Heating and Air Conditioning Auto																			V																																									
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
C	2005	ALL	Body	Heating and Air Conditioning Manual																			V																																									
C	2005	ALL	Body	Instrument Panel Cluster																																																												
C	2005	ALL	Body	Passenger Door Module																																																												
C	2005	ALL	Body	Passenger Presence System																																																												
C	2005	ALL	Body	Base Radio																																																												
C	2005	ALL	Body	Uplevel Radio																																																												
C	2005	ALL	Body	Navigation Radio								V																																																				
C	2005	ALL	Body	Rear Aux. Climate Module																																																												
C	2005	ALL	Body	Rear HVAC																																																												
C	2005	ALL	Body	Rear Seat Audio																																																												
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																	V	V										
C	2005	ALL	Body	Vehicle Theft Deterrent		V																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM			V	V	V																																																							
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM			V	V	V																																																							
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM			V	V	V																																																							
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																							
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																							
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module			V	V	V																																																							
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																							
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module			V	V	V																																																							
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module					V																																																							
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module				V	V																																																							
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module				V	V																																																							
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module					V																																																							
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																									
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																				
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module			V	V	V																																																					
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																										
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																			V																																								
C	2006	ALL	Body	Generator Battery Control Module																																																											
C	2006	ALL	Body	Heating and Air Conditioning Auto																			V																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2006	ALL	Body	Heating and Air Conditioning Manual																			V																																								
C	2006	ALL	Body	Instrument Panel Cluster																																																											
C	2006	ALL	Body	Passenger Door Module																																																											
C	2006	ALL	Body	Passenger Presence System																																																											
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio								V																																																		
C	2006	ALL	Body	Rear Aux. Climate Module																																																											
C	2006	ALL	Body	Rear HVAC																																																											
C	2006	ALL	Body	Rear Seat Audio																																																											
C	2006	ALL	Body	Supplemental Inflatable Restraint	V																																																										
C	2006	ALL	Body	Vehicle Theft Deterrent		V																																																									
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																V	V	V							
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																					
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES													V																																													
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES													V																																													
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW													V																																													
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2007	Avalanche	Body	Amplifier (Bose)																																																											
C	2007	Avalanche	Body	Assist Step Controller																																																											
C	2007	Avalanche	Body	Body Control Module			V																													V																												
C	2007	Avalanche	Body	Body Control Module (aux.)																																																											
C	2007	Avalanche	Body	Digital Radio Receiver																																																											
C	2007	Avalanche	Body	Driver Door Switch																																																											
C	2007	Avalanche	Body	HVAC Control Module Auto																																																											
C	2007	Avalanche	Body	HVAC Control Module Manual																																																											
C	2007	Avalanche	Body	Instrument Panel Cluster																																																											
C	2007	Avalanche	Body	Memory Seat Module																					V	V																																						
C	2007	Avalanche	Body	Park Assist Module																																																											
C	2007	Avalanche	Body	Passenger Door Switch																																																											
C	2007	Avalanche	Body	Passenger Presence System																																																											
C	2007	Avalanche	Body	Radio																																																											
C	2007	Avalanche	Body	Rear Heated Seat Module																																																											
C	2007	Avalanche	Body	Rear HVAC/RSA																																																											
C	2007	Avalanche	Body	Rollover Sensor																																																											
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																			V																																								
C	2007	Avalanche	Body	Theft Deterrent Module		V																																																									
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																						
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																						
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																						
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																						
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																						
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES													V																																														
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES													V																																														
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																														
C	2007	Suburban	Chassis	Electronic Suspension Control																																																											
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																											
C	2007	Suburban	Body	Amplifier (Bose)																																																											
C	2007	Suburban	Body	Assist Step Controller																																																											
C	2007	Suburban	Body	Body Control Module			V																													V																												
C	2007	Suburban	Body	Body Control Module (aux.)																																																											
C	2007	Suburban	Body	Digital Radio Receiver																																																											
C	2007	Suburban	Body	Driver Door Switch																																																											
C	2007	Suburban	Body	HVAC Control Module Auto																																																											
C	2007	Suburban	Body	HVAC Control Module Manual																																																											
C	2007	Suburban	Body	Instrument Panel Cluster																																																											
C	2007	Suburban	Body	Lift Gate Module																																																											
C	2007	Suburban	Body	Memory Seat Module																					V	V																																						
C	2007	Suburban	Body	Park Assist Module																																																											
C	2007	Suburban	Body	Passenger Door Switch																																																											
C	2007	Suburban	Body	Passenger Presence System																																																											
C	2007	Suburban	Body	Radio																																																											
C	2007	Suburban	Body	Rear Heated Seat Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2007	Suburban	Body	Rear HVAC/RSA																																																										
C	2007	Suburban	Body	Rollover Sensor																																																										
C	2007	Suburban	Body	Supplemental Inflatable Restraint																			V																																							
C	2007	Suburban	Body	Theft Deterrent Module		V																																																								
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																						
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																						
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																						
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																						
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																						
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																						
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																						
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																						
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																				V		
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																													
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																													
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW													V																																													
C	2007	Silverado	Chassis	Electronic Suspension Control																																																										
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																										
C	2007	Silverado	Body	Amplifier (Bose)																																																										
C	2007	Silverado	Body	Body Control Module			V																													V																										
C	2007	Silverado	Body	Body Control Module (aux.)																																																										
C	2007	Silverado	Body	Digital Radio Receiver																																																										
C	2007	Silverado	Body	Driver Door Switch																																																										
C	2007	Silverado	Body	HVAC Control Module Auto																																																										
C	2007	Silverado	Body	HVAC Control Module Manual																																																										
C	2007	Silverado	Body	Instrument Panel Cluster																																																										
C	2007	Silverado	Body	Memory Seat Module																					V	V																																				
C	2007	Silverado	Body	Park Assist Module																																																										
C	2007	Silverado	Body	Passenger Door Switch																																																										
C	2007	Silverado	Body	Passenger Presence System																																																										
C	2007	Silverado	Body	Radio																																																										
C	2007	Silverado	Body	Rear Heated Seat Module																																																										
C	2007	Silverado	Body	Rear HVAC/RSA																																																										
C	2007	Silverado	Body	Rollover Sensor																																																										
C	2007	Silverado	Body	Supplemental Inflatable Restraint																			V																																							
C	2007	Silverado	Body	Theft Deterrent Module		V																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES													V																																												
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2007	Tahoe	Body	Amplifier (Bose)																																																										
C	2007	Tahoe	Body	Assist Step Controller																																																										
C	2007	Tahoe	Body	Body Control Module			V																													V																											
C	2007	Tahoe	Body	Body Control Module (aux.)																																																										
C	2007	Tahoe	Body	Digital Radio Receiver																																																										
C	2007	Tahoe	Body	Driver Door Switch																																																										
C	2007	Tahoe	Body	HVAC Control Module Auto																																																										
C	2007	Tahoe	Body	HVAC Control Module Manual																																																										
C	2007	Tahoe	Body	Instrument Panel Cluster																																																										
C	2007	Tahoe	Body	Lift Gate Module																																																										
C	2007	Tahoe	Body	Memory Seat Module																					V	V																																				
C	2007	Tahoe	Body	Park Assist Module																																																										
C	2007	Tahoe	Body	Passenger Door Switch																																																										
C	2007	Tahoe	Body	Passenger Presence System																																																										
C	2007	Tahoe	Body	Radio																																																										
C	2007	Tahoe	Body	Rear Heated Seat Module																																																										
C	2007	Tahoe	Body	Rear HVAC/RSA																																																										
C	2007	Tahoe	Body	Rollover Sensor																																																										
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																			V																																							
C	2007	Tahoe	Body	Theft Deterrent Module		V																																																								
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																					
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Brake Control Module													V																																													
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2008	Avalanche	Body	Amplifier (Bose)																																																										
C	2008	Avalanche	Body	Assist Step Controller																																																										
C	2008	Avalanche	Body	Body Control Module			V																													V																											
C	2008	Avalanche	Body	Body Control Module (aux.)																																																										
C	2008	Avalanche	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2008	Avalanche	Body	Driver Door Switch																																																								
C	2008	Avalanche	Body	HVAC Control Module Auto																																																								
C	2008	Avalanche	Body	HVAC Control Module Manual																																																								
C	2008	Avalanche	Body	Instrument Panel Cluster																																																								
C	2008	Avalanche	Body	Memory Seat Module																					V	V																																			
C	2008	Avalanche	Body	Park Assist Module																																																								
C	2008	Avalanche	Body	Passenger Door Switch																																																								
C	2008	Avalanche	Body	Passenger Presence System																																																								
C	2008	Avalanche	Body	Radio																																																								
C	2008	Avalanche	Body	Rear Heated Seat Module																																																								
C	2008	Avalanche	Body	Rear HVAC/RSA																																																								
C	2008	Avalanche	Body	Rollover Sensor																																																								
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																			V																																					
C	2008	Avalanche	Body	Theft Deterrent Module		V																																																							
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																			
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																			
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																			
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																			
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																			
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES													V																																											
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																											
C	2008	Suburban	Chassis	Electronic Suspension Control																																																								
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																								
C	2008	Suburban	Body	Amplifier (Bose)																																																								
C	2008	Suburban	Body	Assist Step Controller																																																								
C	2008	Suburban	Body	Body Control Module			V																													V																									
C	2008	Suburban	Body	Body Control Module (aux.)																																																								
C	2008	Suburban	Body	Digital Radio Receiver																																																								
C	2008	Suburban	Body	Driver Door Switch																																																								
C	2008	Suburban	Body	HVAC Control Module Auto																																																								
C	2008	Suburban	Body	HVAC Control Module Manual																																																								
C	2008	Suburban	Body	Instrument Panel Cluster																																																								
C	2008	Suburban	Body	Lift Gate Module																																																								
C	2008	Suburban	Body	Memory Seat Module																					V	V																																			
C	2008	Suburban	Body	Park Assist Module																																																								
C	2008	Suburban	Body	Passenger Door Switch																																																								
C	2008	Suburban	Body	Passenger Presence System																																																								
C	2008	Suburban	Body	Radio																																																								
C	2008	Suburban	Body	Rear Heated Seat Module																																																								
C	2008	Suburban	Body	Rear HVAC/RSA																																																								
C	2008	Suburban	Body	Rollover Sensor																																																								
C	2008	Suburban	Body	Supplemental Inflatable Restraint																			V																																					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2008	Suburban	Body	Theft Deterrent Module		V																																																								
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																					
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																					
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																					
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																					
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																												
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
C	2008	Silverado	Chassis	Electronic Suspension Control																																																									
C	2008	Silverado	Chassis	Trailer Brake Control Module																																																									
C	2008	Silverado	Body	Amplifier (Bose)																																																									
C	2008	Silverado	Body	Body Control Module			V																													V																									
C	2008	Silverado	Body	Body Control Module (aux.)																																																									
C	2008	Silverado	Body	Digital Radio Receiver																																																									
C	2008	Silverado	Body	Driver Door Switch																																																									
C	2008	Silverado	Body	HVAC Control Module Auto																																																									
C	2008	Silverado	Body	HVAC Control Module Manual																																																									
C	2008	Silverado	Body	Instrument Panel Cluster																																																									
C	2008	Silverado	Body	Memory Seat Module																					V	V																																			
C	2008	Silverado	Body	Park Assist Module																																																									
C	2008	Silverado	Body	Passenger Door Switch																																																									
C	2008	Silverado	Body	Passenger Presence System																																																									
C	2008	Silverado	Body	Radio																																																									
C	2008	Silverado	Body	Rear Heated Seat Module																																																									
C	2008	Silverado	Body	Rear HVAC/RSA																																																									
C	2008	Silverado	Body	Rollover Sensor																																																									
C	2008	Silverado	Body	Supplemental Inflatable Restraint																			V																																						
C	2008	Silverado	Body	Theft Deterrent Module		V																																																								
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																																										
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																						
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
C	2008	Tahoe	Chassis	Electronic Brake Control Module													V																																													
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																											
C	2008	Tahoe	Body	Amplifier (Bose)																																																											
C	2008	Tahoe	Body	Assist Step Controller																																																											
C	2008	Tahoe	Body	Body Control Module			V																													V																												
C	2008	Tahoe	Body	Body Control Module (aux.)																																																											
C	2008	Tahoe	Body	Digital Radio Receiver																																																											
C	2008	Tahoe	Body	Driver Door Switch																																																											
C	2008	Tahoe	Body	HVAC Control Module Auto																																																											
C	2008	Tahoe	Body	HVAC Control Module Manual																																																											
C	2008	Tahoe	Body	Instrument Panel Cluster																																																											
C	2008	Tahoe	Body	Memory Seat Module																					V	V																																						
C	2008	Tahoe	Body	Park Assist Module																																																											
C	2008	Tahoe	Body	Passenger Presence System																																																											
C	2008	Tahoe	Body	Radio																																																											
C	2008	Tahoe	Body	Rear Heated Seat Module																																																											
C	2008	Tahoe	Body	Rear HVAC/RSA																																																											
C	2008	Tahoe	Body	Rollover Sensor																																																											
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																			V																																								
C	2008	Tahoe	Body	Theft Deterrent Module		V																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V					
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																											
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2008	Tahoe Hybrid	Body	Body Control Module			V																													V																												
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																																											
C	2008	Tahoe Hybrid	Body	HVAC Control Module																																																											
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
C	2008	Tahoe Hybrid	Body	Memory Seat Module																					V	V																																						
C	2008	Tahoe Hybrid	Body	Park Assist Module																																																											
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2008	Tahoe Hybrid	Body	Radio																																																												
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																																												
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																			V																																									
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module		V																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																							
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																							
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																												
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																												
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																							
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																							
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Avalanche	Chassis	Electronic Brake Control Module													V																																															
C	2009	Avalanche	Chassis	Electronic Suspension Control																																																												
C	2009	Avalanche	Chassis	Trailer Brake Control Module																																																												
C	2009	Avalanche	Body	Amplifier (Bose)																																																												
C	2009	Avalanche	Body	Assist Step Controller																																																												
C	2009	Avalanche	Body	Body Control Module			V																														V																											
C	2009	Avalanche	Body	Body Control Module (aux.)																																																												
C	2009	Avalanche	Body	Digital Radio Receiver																																																												
C	2009	Avalanche	Body	Driver Door Switch																																																												
C	2009	Avalanche	Body	HVAC Control Module Auto																																																												
C	2009	Avalanche	Body	HVAC Control Module Manual																																																												
C	2009	Avalanche	Body	Instrument Panel Cluster																																																												
C	2009	Avalanche	Body	Memory Seat Module																					V	V																																						
C	2009	Avalanche	Body	Park Assist Module																																																												
C	2009	Avalanche	Body	Passenger Door Switch																																																												
C	2009	Avalanche	Body	Passenger Presence System																																																												
C	2009	Avalanche	Body	Radio																																																												
C	2009	Avalanche	Body	Rear Heated Seat Module																																																												
C	2009	Avalanche	Body	Rear HVAC/RSA																																																												
C	2009	Avalanche	Body	Rollover Sensor																																																												
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																			V																																									
C	2009	Avalanche	Body	Theft Deterrent Module		V																																																										
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																							
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																							
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES													V																																															

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																												
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES													V																																												
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																										
C	2009	Cheyenne	Body	Amplifier (Bose)																																																										
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2009	Cheyenne	Body	Digital Radio Receiver																																																										
C	2009	Cheyenne	Body	Driver Door Switch																																																										
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2009	Cheyenne	Body	Park Assist Module																																																										
C	2009	Cheyenne	Body	Passenger Door Switch																																																										
C	2009	Cheyenne	Body	Passenger Presence System																																																										
C	2009	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2009	Cheyenne	Body	Rollover Sensor																																																										
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																			V																																							
C	2009	Cheyenne	Body	Theft Deterrent Module		V																																																									
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																						
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																						
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																						
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																						
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																						
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																						
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2009	Suburban	Chassis	EBCM Under 8600 GVW													V																																													
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																													
C	2009	Suburban	Chassis	Electronic Suspension Control																																																										
C	2009	Suburban	Chassis	Trailer Brake Control Module																																																										
C	2009	Suburban	Body	Amplifier (Bose)																																																										
C	2009	Suburban	Body	Assist Step Controller																																																										
C	2009	Suburban	Body	Body Control Module			V																													V																											
C	2009	Suburban	Body	Body Control Module (aux.)																																																										
C	2009	Suburban	Body	Digital Radio Receiver																																																										
C	2009	Suburban	Body	Driver Door Switch																																																										
C	2009	Suburban	Body	HVAC Control Module Auto																																																										
C	2009	Suburban	Body	HVAC Control Module Manual																																																										
C	2009	Suburban	Body	Instrument Panel Cluster																																																										
C	2009	Suburban	Body	Left Side Object Detection Module																																																										
C	2009	Suburban	Body	Lift Gate Module																																																										
C	2009	Suburban	Body	Memory Seat Module																					V	V																																				
C	2009	Suburban	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2009	Suburban	Body	Passenger Door Switch																																																										
C	2009	Suburban	Body	Passenger Presence System																																																										
C	2009	Suburban	Body	Radio																																																										
C	2009	Suburban	Body	Rear Heated Seat Module																																																										
C	2009	Suburban	Body	Rear HVAC/RSA																																																										
C	2009	Suburban	Body	Right Side Object Detection Module																																																										
C	2009	Suburban	Body	Rollover Sensor																																																										
C	2009	Suburban	Body	Supplemental Inflatable Restraint																			V																																							
C	2009	Suburban	Body	Theft Deterrent Module		V																																																								
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																			V		
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																						
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																						
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																					
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual			V		V																																																			V		
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																					
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																					
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																			V		
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																													
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																													
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES													V																																													
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																													
C	2009	Silverado	Chassis	Electronic Suspension Control																																																										
C	2009	Silverado	Chassis	Trailer Brake Control Module																																																										
C	2009	Silverado	Body	Amplifier (Bose)																																																										
C	2009	Silverado	Body	Body Control Module			V																													V																										
C	2009	Silverado	Body	Body Control Module (aux.)																																																										
C	2009	Silverado	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2009	Silverado	Body	Driver Door Switch																																																									
C	2009	Silverado	Body	HVAC Control Module Auto																																																									
C	2009	Silverado	Body	HVAC Control Module Manual																																																									
C	2009	Silverado	Body	Instrument Panel Cluster																																																									
C	2009	Silverado	Body	Memory Seat Module																					V	V																																			
C	2009	Silverado	Body	Park Assist Module																																																									
C	2009	Silverado	Body	Passenger Door Switch																																																									
C	2009	Silverado	Body	Passenger Presence System																																																									
C	2009	Silverado	Body	Radio																																																									
C	2009	Silverado	Body	Rear Heated Seat Module																																																									
C	2009	Silverado	Body	Rear HVAC/RSA																																																									
C	2009	Silverado	Body	Rollover Sensor																																																									
C	2009	Silverado	Body	Supplemental Inflatable Restraint																			V																																						
C	2009	Silverado	Body	Theft Deterrent Module		V																																																							
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V					
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																									
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																									
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																									
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																									
C	2009	Silverado Hybrid	Body	Body Control Module			V																													V																									
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																									
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																									
C	2009	Silverado Hybrid	Body	Driver Door Switch																																																									
C	2009	Silverado Hybrid	Body	HVAC Control Module																																																									
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																									
C	2009	Silverado Hybrid	Body	Memory Seat Module																					V	V																																			
C	2009	Silverado Hybrid	Body	Park Assist Module																																																									
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																																									
C	2009	Silverado Hybrid	Body	Passenger Presence System																																																									
C	2009	Silverado Hybrid	Body	Radio																																																									
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																									
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																									
C	2009	Silverado Hybrid	Body	Rollover Sensor																																																									
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																									
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																			V																																						
C	2009	Silverado Hybrid	Body	Theft Deterrent Module		V																																																							
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																				
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																				
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																						
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																						
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2009	Tahoe	Chassis	Electronic Brake Control Module													V																																														
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																																											
C	2009	Tahoe	Body	Amplifier (Bose)																																																											
C	2009	Tahoe	Body	Assist Step Controller																																																											
C	2009	Tahoe	Body	Body Control Module			V																													V																												
C	2009	Tahoe	Body	Body Control Module (aux.)																																																											
C	2009	Tahoe	Body	Digital Radio Receiver																																																											
C	2009	Tahoe	Body	Driver Door Switch																																																											
C	2009	Tahoe	Body	HVAC Control Module Auto																																																											
C	2009	Tahoe	Body	HVAC Control Module Manual																																																											
C	2009	Tahoe	Body	Instrument Panel Cluster																																																											
C	2009	Tahoe	Body	Left Side Object Detection Module																																																											
C	2009	Tahoe	Body	Lift Gate Module																																																											
C	2009	Tahoe	Body	Memory Seat Module																					V	V																																					
C	2009	Tahoe	Body	Park Assist Module																																																											
C	2009	Tahoe	Body	Passenger Door Switch																																																											
C	2009	Tahoe	Body	Passenger Presence System																																																											
C	2009	Tahoe	Body	Radio																																																										
C	2009	Tahoe	Body	Rear Heated Seat Module																																																											
C	2009	Tahoe	Body	Rear HVAC/RSA																																																											
C	2009	Tahoe	Body	Right Side Object Detection Module																																																											
C	2009	Tahoe	Body	Rollover Sensor																																																											
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																			V																																								
C	2009	Tahoe	Body	Theft Deterrent Module		V																																																									
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																					V			
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																											
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2009	Tahoe Hybrid	Body	Body Control Module			V																													V																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2009	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2009	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2009	Tahoe Hybrid	Body	Radio																																																										
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																										
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																			V																																							
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module		V																																																								
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V					
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																V					
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Avalanche	Chassis	Electronic Brake Control Module													V																																													
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Avalanche	Body	Amplifier (Bose)																																																										
C	2010	Avalanche	Body	Assist Step Controller																																																										
C	2010	Avalanche	Body	Body Control Module			V																													V																										
C	2010	Avalanche	Body	Body Control Module (aux.)																																																										
C	2010	Avalanche	Body	Digital Radio Receiver																																																										
C	2010	Avalanche	Body	Driver Door Switch																																																										
C	2010	Avalanche	Body	HVAC Control Module Auto																																																										
C	2010	Avalanche	Body	HVAC Control Module Manual																																																										
C	2010	Avalanche	Body	Instrument Panel Cluster																																																										
C	2010	Avalanche	Body	Memory Seat Module																					V	V																																				
C	2010	Avalanche	Body	Park Assist Module																																																										
C	2010	Avalanche	Body	Passenger Door Switch																																																										
C	2010	Avalanche	Body	Passenger Presence System																																																										
C	2010	Avalanche	Body	Radio																																																										
C	2010	Avalanche	Body	Rear Heated Seat Module																																																										
C	2010	Avalanche	Body	Rear HVAC/RSA																																																										
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2010	Avalanche	Body	Theft Deterrent Module		V																																																								
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V					
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																V					
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES													V																																													
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES													V																																													
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																													
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES													V																																													
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Cheyenne	Body	Amplifier (Bose)																																																											
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																											
C	2010	Cheyenne	Body	Digital Radio Receiver																																																											
C	2010	Cheyenne	Body	Driver Door Switch																																																											
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																											
C	2010	Cheyenne	Body	Park Assist Module																																																											
C	2010	Cheyenne	Body	Passenger Door Switch																																																											
C	2010	Cheyenne	Body	Passenger Presence System																																																											
C	2010	Cheyenne	Body	Rear Heated Seat Module																																																											
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																											
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
C	2010	Cheyenne	Body	Theft Deterrent Module		V																																																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																							
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																		V				
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																	V				
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																	V				
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
C	2010	Suburban	Chassis	EBCM Under 8600 GVW													V																																														
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																															
C	2010	Suburban	Chassis	Electronic Suspension Control																																																												
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Suburban	Body	Amplifier (Bose)																																																												
C	2010	Suburban	Body	Assist Step Controller																																																												
C	2010	Suburban	Body	Body Control Module			V																													V																												
C	2010	Suburban	Body	Body Control Module (aux.)																																																												
C	2010	Suburban	Body	Digital Radio Receiver																																																												
C	2010	Suburban	Body	Driver Door Switch																																																												
C	2010	Suburban	Body	HVAC Control Module Auto																																																												
C	2010	Suburban	Body	HVAC Control Module Manual																																																												
C	2010	Suburban	Body	Instrument Panel Cluster																																																												
C	2010	Suburban	Body	Left Side Object Detection Module																																																												
C	2010	Suburban	Body	Lift Gate Module																																																												
C	2010	Suburban	Body	Memory Seat Module																					V	V																																						
C	2010	Suburban	Body	Park Assist Module																																																												
C	2010	Suburban	Body	Passenger Door Switch																																																												
C	2010	Suburban	Body	Passenger Presence System																																																												
C	2010	Suburban	Body	Radio																																																											
C	2010	Suburban	Body	Rear Heated Seat Module																																																												
C	2010	Suburban	Body	Rear HVAC/RSA																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2010	Suburban	Body	Right Side Object Detection Module																																																										
C	2010	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2010	Suburban	Body	Theft Deterrent Module		V																																																								
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic					V																																															V			V
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual					V																																																V		
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V			
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V			
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																															V			
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V			
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic					V																																															V			V
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual					V																																																V		
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																															V			
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																															V			
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																												
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES													V																																												
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																												
C	2010	Silverado	Chassis	Electronic Suspension Control																																																									
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
C	2010	Silverado	Body	Amplifier (Bose)																																																								
C	2010	Silverado	Body	Body Control Module			V																													V																									
C	2010	Silverado	Body	Body Control Module (aux.)																																																									
C	2010	Silverado	Body	Digital Radio Receiver																																																									
C	2010	Silverado	Body	Driver Door Switch																																																									
C	2010	Silverado	Body	HVAC Control Module Auto																																																									
C	2010	Silverado	Body	HVAC Control Module Manual																																																									
C	2010	Silverado	Body	Instrument Panel Cluster																																																									
C	2010	Silverado	Body	Memory Seat Module																					V	V																																				
C	2010	Silverado	Body	Park Assist Module																																																									
C	2010	Silverado	Body	Passenger Door Switch																																																									
C	2010	Silverado	Body	Passenger Presence System																																																									
C	2010	Silverado	Body	Radio																																																									
C	2010	Silverado	Body	Rear Heated Seat Module																																																									
C	2010	Silverado	Body	Rear HVAC/RSA																																																									
C	2010	Silverado	Body	Supplemental Inflatable Restraint																																																									
C	2010	Silverado	Body	Theft Deterrent Module		V																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																V			
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																								
C	2010	Silverado Hybrid	Body	Body Control Module			V																													V																									
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																								
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																								
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																								
C	2010	Silverado Hybrid	Body	HVAC Control Module																																																								
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
C	2010	Silverado Hybrid	Body	Park Assist Module																																																								
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																								
C	2010	Silverado Hybrid	Body	Passenger Presence System																																																								
C	2010	Silverado Hybrid	Body	Radio																																																								
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2010	Silverado Hybrid	Body	Theft Deterrent Module		V																																																						
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																V			
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																		
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2010	Tahoe	Chassis	Electronic Brake Control Module													V																																											
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																								
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Tahoe	Body	Amplifier (Bose)																																																								
C	2010	Tahoe	Body	Assist Step Controller																																																								
C	2010	Tahoe	Body	Body Control Module			V																													V																									
C	2010	Tahoe	Body	Body Control Module (aux.)																																																								
C	2010	Tahoe	Body	Digital Radio Receiver																																																								
C	2010	Tahoe	Body	Driver Door Switch																																																								
C	2010	Tahoe	Body	HVAC Control Module Auto																																																								
C	2010	Tahoe	Body	HVAC Control Module Manual																																																								
C	2010	Tahoe	Body	Instrument Panel Cluster																																																								
C	2010	Tahoe	Body	Left Side Object Detection Module																																																								
C	2010	Tahoe	Body	Lift Gate Module																																																								
C	2010	Tahoe	Body	Memory Seat Module																					V	V																																		

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2010	Tahoe	Body	Park Assist Module																																																												
C	2010	Tahoe	Body	Passenger Door Switch																																																												
C	2010	Tahoe	Body	Passenger Presence System																																																												
C	2010	Tahoe	Body	Radio																																																												
C	2010	Tahoe	Body	Rear Heated Seat Module																																																												
C	2010	Tahoe	Body	Rear HVAC/RSA																																																												
C	2010	Tahoe	Body	Right Side Object Detection Module																																																												
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2010	Tahoe	Body	Theft Deterrent Module		V																																																										
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																	V						
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2010	Tahoe Hybrid	Body	Body Control Module			V																		V											V																												
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																																												
C	2010	Tahoe Hybrid	Body	HVAC Control Module																																																												
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																																												
C	2010	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																												
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																																												
C	2010	Tahoe Hybrid	Body	Radio																																																												
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module		V																																																										
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																	V						
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																	V						
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2011	Avalanche	Chassis	Electronic Brake Control Module												V																																																
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																												
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2011	Avalanche	Body	Amplifier (Bose)																																																										
C	2011	Avalanche	Body	Assist Step Controller																																																										
C	2011	Avalanche	Body	Body Control Module			V																													V																										
C	2011	Avalanche	Body	Body Control Module (aux.)																																																										
C	2011	Avalanche	Body	Digital Radio Receiver																																																										
C	2011	Avalanche	Body	Driver Door Switch																																																										
C	2011	Avalanche	Body	HVAC Control Module Auto																																																										
C	2011	Avalanche	Body	HVAC Control Module Manual																																																										
C	2011	Avalanche	Body	Instrument Panel Cluster																																																										
C	2011	Avalanche	Body	Memory Seat Module																					V	V																																					
C	2011	Avalanche	Body	Park Assist Module																																																										
C	2011	Avalanche	Body	Passenger Door Switch																																																										
C	2011	Avalanche	Body	Passenger Presence System																																																										
C	2011	Avalanche	Body	Radio																																																										
C	2011	Avalanche	Body	Rear Heated Seat Module																																																										
C	2011	Avalanche	Body	Rear HVAC/RSA																																																										
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2011	Avalanche	Body	Theft Deterrent Module		V																																																								
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2011	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2011	Captiva	Chassis	Parking Brake Control Module																																																										
C	2011	Captiva	Body	Body Control Module																																																										
C	2011	Captiva	Body	Auxiliary Body Control Module																																																										
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2011	Captiva	Body	Instrument Cluster																																																										
C	2011	Captiva	Body	Headlamp Control Module																																																										
C	2011	Captiva	Body	HVAC Control Module																																																										
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																										
C	2011	Captiva	Body	Parking Assist Control Module																																																										
C	2011	Captiva	Body	Theft Deterrent Module		V																																																								
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																V				
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V				

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES													V																																													
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES													V																																													
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																													
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES													V																																													
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																											
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
C	2011	Cheyenne	Body	Amplifier (Bose)																																																											
C	2011	Cheyenne	Body	Body Control Module			V																													V																												
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																											
C	2011	Cheyenne	Body	Digital Radio Receiver																																																											
C	2011	Cheyenne	Body	Driver Door Switch																																																											
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																											
C	2011	Cheyenne	Body	Park Assist Module																																																											
C	2011	Cheyenne	Body	Passenger Door Switch																																																											
C	2011	Cheyenne	Body	Passenger Presence System																																																											
C	2011	Cheyenne	Body	Rear Heated Seat Module																																																											
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																											
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
C	2011	Cheyenne	Body	Theft Deterrent Module		V																																																									
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																V				
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																						
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																V				
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																														
C	2011	Suburban	Chassis	EBCM Under 8600 GVW													V																																														
C	2011	Suburban	Chassis	Electronic Suspension Control																																																												
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
C	2011	Suburban	Body	Amplifier (Bose)																																																												
C	2011	Suburban	Body	Assist Step Controller																																																												
C	2011	Suburban	Body	Body Control Module			V																													V																												
C	2011	Suburban	Body	Body Control Module (aux.)																																																												
C	2011	Suburban	Body	Digital Radio Receiver																																																												
C	2011	Suburban	Body	Driver Door Switch																																																												
C	2011	Suburban	Body	HVAC Control Module Auto																																																												
C	2011	Suburban	Body	HVAC Control Module Manual																																																												
C	2011	Suburban	Body	Instrument Panel Cluster																																																												
C	2011	Suburban	Body	Left Side Object Detection Module																																																												
C	2011	Suburban	Body	Lift Gate Module																																																												
C	2011	Suburban	Body	Memory Seat Module																					V	V																																						
C	2011	Suburban	Body	Park Assist Module																																																												
C	2011	Suburban	Body	Passenger Door Switch																																																												
C	2011	Suburban	Body	Passenger Presence System																																																												
C	2011	Suburban	Body	Radio																																																												
C	2011	Suburban	Body	Rear Heated Seat Module																																																												
C	2011	Suburban	Body	Rear HVAC/RSA																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2011	Suburban	Body	Right Side Object Detection Module																																																									
C	2011	Suburban	Body	Supplemental Inflatable Restraint																																																									
C	2011	Suburban	Body	Theft Deterrent Module		V																																																							
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic					V																																														V			V
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual					V																																															V		
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																														V			
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																							
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																														V			
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																							
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																														V			
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																							
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic					V																																														V			V
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual					V																																														V	V		
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																														V			
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																							
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																							
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module					V																																														V			
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																							
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																							
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																							
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																														V			
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																							
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																							
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																							
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																											
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																											
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES													V																																											
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																											
C	2011	Silverado	Chassis	Electronic Suspension Control																																																							
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																							
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																							
C	2011	Silverado	Body	Amplifier (Bose)																																																							
C	2011	Silverado	Body	Body Control Module			V																													V																								
C	2011	Silverado	Body	Body Control Module (aux.)																																																							
C	2011	Silverado	Body	Digital Radio Receiver																																																							
C	2011	Silverado	Body	Driver Door Switch																																																							
C	2011	Silverado	Body	HVAC Control Module Auto																																																							
C	2011	Silverado	Body	HVAC Control Module Manual																																																							
C	2011	Silverado	Body	Instrument Panel Cluster																																																							
C	2011	Silverado	Body	Memory Seat Module																					V	V																																		
C	2011	Silverado	Body	Park Assist Module																																																							
C	2011	Silverado	Body	Passenger Door Switch																																																							
C	2011	Silverado	Body	Passenger Presence System																																																							
C	2011	Silverado	Body	Radio																																																							
C	2011	Silverado	Body	Rear Heated Seat Module																																																							
C	2011	Silverado	Body	Rear HVAC/RSA																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2011	Silverado	Body	Theft Deterrent Module		V																																																									
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																		V			
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Silverado Hybrid	Body	Body Control Module			V																													V																											
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2011	Silverado Hybrid	Body	HVAC Control Module																																																										
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Silverado Hybrid	Body	Park Assist Module																																																										
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2011	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2011	Silverado Hybrid	Body	Radio																																																										
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2011	Silverado Hybrid	Body	Theft Deterrent Module		V																																																								
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																					
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Tahoe	Chassis	Electronic Brake Control Module													V																																													
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe	Body	Amplifier (Bose)																																																										
C	2011	Tahoe	Body	Assist Step Controller																																																										
C	2011	Tahoe	Body	Body Control Module			V																													V																											
C	2011	Tahoe	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe	Body	Digital Radio Receiver																																																										
C	2011	Tahoe	Body	Driver Door Switch																																																										
C	2011	Tahoe	Body	HVAC Control Module Auto																																																										
C	2011	Tahoe	Body	HVAC Control Module Manual																																																										
C	2011	Tahoe	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe	Body	Left Side Object Detection Module																																																										
C	2011	Tahoe	Body	Lift Gate Module																																																										
C	2011	Tahoe	Body	Memory Seat Module																					V	V																																				
C	2011	Tahoe	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2011	Tahoe	Body	Passenger Door Switch																																																										
C	2011	Tahoe	Body	Passenger Presence System																																																										
C	2011	Tahoe	Body	Radio																																																										
C	2011	Tahoe	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe	Body	Right Side Object Detection Module																																																										
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2011	Tahoe	Body	Theft Deterrent Module		V																																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																V					
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Tahoe Hybrid	Body	Body Control Module			V																													V																										
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2011	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2011	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2011	Tahoe Hybrid	Body	Radio																																																										
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module		V																																																								
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																																V					
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V					
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Avalanche	Chassis	Electronic Brake Control Module												V																																														
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2012	Avalanche	Body	Amplifier (Bose)																																																								
C	2012	Avalanche	Body	Assist Step Controller																																																								
C	2012	Avalanche	Body	Body Control Module			V																													V			V																						
C	2012	Avalanche	Body	Body Control Module (aux.)																																																								
C	2012	Avalanche	Body	Digital Radio Receiver																																																								
C	2012	Avalanche	Body	Driver Door Switch																																																								
C	2012	Avalanche	Body	HVAC Control Module Auto																																																								
C	2012	Avalanche	Body	HVAC Control Module Manual																																																								
C	2012	Avalanche	Body	Instrument Panel Cluster																																																								
C	2012	Avalanche	Body	Memory Seat Module																					V	V																																				
C	2012	Avalanche	Body	Navigation Radio																																																								
C	2012	Avalanche	Body	Park Assist Module																																																								
C	2012	Avalanche	Body	Passenger Door Switch																																																								
C	2012	Avalanche	Body	Passenger Presence System																																																								
C	2012	Avalanche	Body	Radio																																																								
C	2012	Avalanche	Body	Rear Heated Seat Module																																																								
C	2012	Avalanche	Body	Rear HVAC/RSA																																																								
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																								
C	2012	Avalanche	Body	Theft Deterrent Module		V																																																							
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																								
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																								
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																								
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																								
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																								
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																								
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																								
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																								
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																								
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																								
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																								
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																								
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																								
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																								
C	2012	Captiva	Chassis	Parking Brake Control Module																																																								
C	2012	Captiva	Body	Body Control Module																																																								
C	2012	Captiva	Body	Auxiliary Body Control Module																																																								
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2012	Captiva	Body	Instrument Cluster																																																								
C	2012	Captiva	Body	Headlamp Control Module																																																								
C	2012	Captiva	Body	HVAC Control Module																																																								
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																								
C	2012	Captiva	Body	Parking Assist Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2012	Captiva	Body	Theft Deterrent Module		V																																																						
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic					V																																															V			V
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual					V																																																V		
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																															V			
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																							
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V			
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																							
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES													V																																										
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES													V																																										
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																										
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES													V																																										
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																							
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																							
C	2012	Cheyenne	Body	Amplifier (Bose)																																																							
C	2012	Cheyenne	Body	Body Control Module			V																													V			V																					
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																							
C	2012	Cheyenne	Body	Digital Radio Receiver																																																							
C	2012	Cheyenne	Body	Driver Door Switch																																																							
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																							
C	2012	Cheyenne	Body	Park Assist Module																																																							
C	2012	Cheyenne	Body	Passenger Door Switch																																																							
C	2012	Cheyenne	Body	Passenger Presence System																																																							
C	2012	Cheyenne	Body	Rear Heated Seat Module																																																							
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																							
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																							
C	2012	Cheyenne	Body	Theft Deterrent Module		V																																																					
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																															V			
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																							
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																		
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																							
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed					V																																															V			
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
C	2012	Suburban	Chassis	EBCM Under 8600 GVW													V																																										
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																										
C	2012	Suburban	Chassis	Electronic Suspension Control																																																							
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																							
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																							
C	2012	Suburban	Body	Amplifier (Bose)																																																							
C	2012	Suburban	Body	Assist Step Controller																																																							
C	2012	Suburban	Body	Body Control Module			V																													V			V																					
C	2012	Suburban	Body	Body Control Module (aux.)																																																							
C	2012	Suburban	Body	Digital Radio Receiver																																																							
C	2012	Suburban	Body	Driver Door Switch																																																							
C	2012	Suburban	Body	HVAC Control Module Auto																																																							
C	2012	Suburban	Body	HVAC Control Module Manual																																																							
C	2012	Suburban	Body	Instrument Panel Cluster																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2012	Suburban	Body	Left Side Object Detection Module																																																								
C	2012	Suburban	Body	Lift Gate Module																																																								
C	2012	Suburban	Body	Memory Seat Module																					V	V																																			
C	2012	Suburban	Body	Navigation Radio																																																								
C	2012	Suburban	Body	Park Assist Module																																																								
C	2012	Suburban	Body	Passenger Door Switch																																																								
C	2012	Suburban	Body	Passenger Presence System																																																								
C	2012	Suburban	Body	Radio																																																								
C	2012	Suburban	Body	Rear Heated Seat Module																																																								
C	2012	Suburban	Body	Rear HVAC/RSA																																																								
C	2012	Suburban	Body	Right Side Object Detection Module																																																								
C	2012	Suburban	Body	Supplemental Inflatable Restraint																																																								
C	2012	Suburban	Body	Theft Deterrent Module		V																																																							
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic					V																																															V			V
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual					V																																																V		
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V			
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V			
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																															V			
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic					V																																															V			V
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual					V																																															V	V		
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																															V			
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module					V																																															V			
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																															V			
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																											
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																											
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES													V																																											
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																											
C	2012	Silverado	Chassis	Electronic Suspension Control																																																								
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
C	2012	Silverado	Body	Amplifier (Bose)																																																								
C	2012	Silverado	Body	Body Control Module			V																													V			V																					
C	2012	Silverado	Body	Body Control Module (aux.)																																																								
C	2012	Silverado	Body	Digital Radio Receiver																																																								
C	2012	Silverado	Body	Driver Door Switch																																																								
C	2012	Silverado	Body	HVAC Control Module Auto																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2012	Silverado	Body	HVAC Control Module Manual																																																										
C	2012	Silverado	Body	Instrument Panel Cluster																																																										
C	2012	Silverado	Body	Memory Seat Module																					V	V																																				
C	2012	Silverado	Body	Navigation Radio																																																									
C	2012	Silverado	Body	Park Assist Module																																																									
C	2012	Silverado	Body	Passenger Door Switch																																																									
C	2012	Silverado	Body	Passenger Presence System																																																									
C	2012	Silverado	Body	Radio																																																									
C	2012	Silverado	Body	Rear Heated Seat Module																																																									
C	2012	Silverado	Body	Rear HVAC/RSA																																																									
C	2012	Silverado	Body	Supplemental Inflatable Restraint																																																									
C	2012	Silverado	Body	Theft Deterrent Module		V																																																							
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V				
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																									
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																									
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																									
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																									
C	2012	Silverado Hybrid	Body	Body Control Module			V																													V			V																							
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																									
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																									
C	2012	Silverado Hybrid	Body	Driver Door Switch																																																									
C	2012	Silverado Hybrid	Body	Heated Seat Module																																																									
C	2012	Silverado Hybrid	Body	HVAC Control Module																																																									
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																									
C	2012	Silverado Hybrid	Body	Navigation Radio																																																									
C	2012	Silverado Hybrid	Body	Park Assist Module																																																									
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																																									
C	2012	Silverado Hybrid	Body	Passenger Presence System																																																									
C	2012	Silverado Hybrid	Body	Radio																																																									
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																									
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																									
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																									
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																									
C	2012	Silverado Hybrid	Body	Theft Deterrent Module		V																																																							
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																				
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2012	Tahoe	Chassis	Electronic Brake Control Module													V																																												
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																									
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
C	2012	Tahoe	Body	Amplifier (Bose)																																																									
C	2012	Tahoe	Body	Assist Step Controller																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2012	Tahoe	Body	Body Control Module			V																													V			V																					
C	2012	Tahoe	Body	Body Control Module (aux.)																																																								
C	2012	Tahoe	Body	Digital Radio Receiver																																																								
C	2012	Tahoe	Body	Driver Door Switch																																																								
C	2012	Tahoe	Body	HVAC Control Module Auto																																																								
C	2012	Tahoe	Body	HVAC Control Module Manual																																																								
C	2012	Tahoe	Body	Instrument Panel Cluster																																																								
C	2012	Tahoe	Body	Left Side Object Detection Module																																																								
C	2012	Tahoe	Body	Lift Gate Module																																																								
C	2012	Tahoe	Body	Memory Seat Module																					V	V																																				
C	2012	Tahoe	Body	Navigation Radio																																																								
C	2012	Tahoe	Body	Park Assist Module																																																								
C	2012	Tahoe	Body	Passenger Door Switch																																																								
C	2012	Tahoe	Body	Passenger Presence System																																																								
C	2012	Tahoe	Body	Radio																																																								
C	2012	Tahoe	Body	Rear Heated Seat Module																																																								
C	2012	Tahoe	Body	Rear HVAC/RSA																																																								
C	2012	Tahoe	Body	Right Side Object Detection Module																																																								
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																								
C	2012	Tahoe	Body	Theft Deterrent Module		V																																																						
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V				
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
C	2012	Tahoe Hybrid	Body	Body Control Module			V																													V			V																					
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																																								
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																																								
C	2012	Tahoe Hybrid	Body	HVAC Control Module																																																								
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
C	2012	Tahoe Hybrid	Body	Lift Gate Module																																																								
C	2012	Tahoe Hybrid	Body	Navigation Radio																																																								
C	2012	Tahoe Hybrid	Body	Park Assist Module																																																								
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																								
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																																								
C	2012	Tahoe Hybrid	Body	Radio																																																								
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module		V																																																								
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																																V			
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V			
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2013	Avalanche	Chassis	Electronic Brake Control Module													V																																												
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																									
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Avalanche	Body	Amplifier (Bose)																																																									
C	2013	Avalanche	Body	Assist Step Controller																																																									
C	2013	Avalanche	Body	Body Control Module			V																													V			V																							
C	2013	Avalanche	Body	Body Control Module (aux.)																																																									
C	2013	Avalanche	Body	Digital Radio Receiver																																																									
C	2013	Avalanche	Body	Driver Door Switch																																																									
C	2013	Avalanche	Body	HVAC Control Module Auto																																																									
C	2013	Avalanche	Body	HVAC Control Module Manual																																																									
C	2013	Avalanche	Body	Instrument Panel Cluster																																																									
C	2013	Avalanche	Body	Memory Seat Module																					V	V																																			
C	2013	Avalanche	Body	Navigation Radio																																																									
C	2013	Avalanche	Body	Park Assist Module																																																									
C	2013	Avalanche	Body	Passenger Door Switch																																																									
C	2013	Avalanche	Body	Passenger Presence System																																																									
C	2013	Avalanche	Body	Radio																																																									
C	2013	Avalanche	Body	Rear Heated Seat Module																																																									
C	2013	Avalanche	Body	Rear HVAC/RSA																																																									
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																									
C	2013	Avalanche	Body	Theft Deterrent Module		V																																																								
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																									
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																									
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																									
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																									
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																									
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																									
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																									
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																									
C	2013	Captiva	Chassis	Electronic Brake Control Module																																																									
C	2013	Captiva	Chassis	Parking Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																									
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																									
C	2013	Captiva	Body	Auxiliary Body Control Module																																																									
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2013	Captiva	Body	Instrument Cluster																																																									
C	2013	Captiva	Body	Headlamp Control Module																																																									
C	2013	Captiva	Body	HVAC Control Module																																																									
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																									
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																										V															
C	2013	Captiva	Body	Theft Deterrent Module		V																																																							
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic					V																																															V				V
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual					V																																																V			
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																																V				
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V				
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES													V																																												
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																												
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES													V																																												
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																									
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Cheyenne	Body	Amplifier (Bose)																																																									
C	2013	Cheyenne	Body	Body Control Module			V																													V			V																						
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																									
C	2013	Cheyenne	Body	Digital Radio Receiver																																																									
C	2013	Cheyenne	Body	Driver Door Switch																																																									
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																									
C	2013	Cheyenne	Body	Park Assist Module																																																									
C	2013	Cheyenne	Body	Passenger Door Switch																																																									
C	2013	Cheyenne	Body	Passenger Presence System																																																									
C	2013	Cheyenne	Body	Rear Heated Seat Module																																																									
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																									
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																									
C	2013	Cheyenne	Body	Theft Deterrent Module		V																																																							
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																																V				
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																				
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed					V																																																V				
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
C	2013	Suburban	Chassis	EBCM Under 8600 GVW													V																																												
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
C	2013	Suburban	Chassis	Electronic Suspension Control																																																									
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Suburban	Body	Amplifier (Bose)																																																								
C	2013	Suburban	Body	Assist Step Controller																																																								
C	2013	Suburban	Body	Body Control Module			V																												V			V																							
C	2013	Suburban	Body	Body Control Module (aux.)																																																								
C	2013	Suburban	Body	Digital Radio Receiver																																																								
C	2013	Suburban	Body	Driver Door Switch																																																								
C	2013	Suburban	Body	HVAC Control Module Auto																																																								
C	2013	Suburban	Body	HVAC Control Module Manual																																																								
C	2013	Suburban	Body	Instrument Panel Cluster																																																								
C	2013	Suburban	Body	Left Side Object Detection Module																																																								
C	2013	Suburban	Body	Lift Gate Module																																																								
C	2013	Suburban	Body	Memory Seat Module																					V	V																																			
C	2013	Suburban	Body	Navigation Radio																																																								
C	2013	Suburban	Body	Park Assist Module																																																								
C	2013	Suburban	Body	Passenger Door Switch																																																								
C	2013	Suburban	Body	Passenger Presence System																																																								
C	2013	Suburban	Body	Radio																																																								
C	2013	Suburban	Body	Rear Heated Seat Module																																																								
C	2013	Suburban	Body	Rear HVAC/RSA																																																								
C	2013	Suburban	Body	Right Side Object Detection Module																																																								
C	2013	Suburban	Body	Supplemental Inflatable Restraint																																																								
C	2013	Suburban	Body	Theft Deterrent Module		V																																																						
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic					V																																															V			V
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual					V																																																V		
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																														V			
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																														V			
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																														V			
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic					V																																														V			V
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual					V																																														V	V		
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																														V			V
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																								
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																														V			
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module					V																																														V			
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																											
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																											
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES													V																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																											
C	2013	Silverado	Chassis	Electronic Suspension Control																																																								
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
C	2013	Silverado	Body	Amplifier (Bose)																																																								
C	2013	Silverado	Body	Body Control Module			V																		V											V			V																						
C	2013	Silverado	Body	Body Control Module (aux.)																																																								
C	2013	Silverado	Body	Digital Radio Receiver																																																								
C	2013	Silverado	Body	Driver Door Switch																																																								
C	2013	Silverado	Body	HVAC Control Module Auto																																																								
C	2013	Silverado	Body	HVAC Control Module Manual																																																								
C	2013	Silverado	Body	Instrument Panel Cluster																																																								
C	2013	Silverado	Body	Memory Seat Module																					V	V																																			
C	2013	Silverado	Body	Navigation Radio																																																								
C	2013	Silverado	Body	Park Assist Module																																																								
C	2013	Silverado	Body	Passenger Door Switch																																																								
C	2013	Silverado	Body	Passenger Presence System																																																								
C	2013	Silverado	Body	Radio																																																								
C	2013	Silverado	Body	Rear Heated Seat Module																																																								
C	2013	Silverado	Body	Rear HVAC/RSA																																																								
C	2013	Silverado	Body	Supplemental Inflatable Restraint																																																								
C	2013	Silverado	Body	Theft Deterrent Module		V																																																						
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V				
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																								
C	2013	Silverado Hybrid	Body	Body Control Module			V																		V											V			V																						
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																								
C	2013	Silverado Hybrid	Body	Driver Door Switch																																																								
C	2013	Silverado Hybrid	Body	Heated Seat Module																																																								
C	2013	Silverado Hybrid	Body	HVAC Control Module																																																								
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
C	2013	Silverado Hybrid	Body	Navigation Radio																																																								
C	2013	Silverado Hybrid	Body	Park Assist Module																																																								
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																																								
C	2013	Silverado Hybrid	Body	Passenger Presence System																																																								
C	2013	Silverado Hybrid	Body	Radio																																																								
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																									
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																									
C	2013	Silverado Hybrid	Body	Theft Deterrent Module		V																																																							
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																				
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2013	Tahoe	Chassis	Electronic Brake Control Module													V																																												
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																									
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Tahoe	Body	Amplifier (Bose)																																																									
C	2013	Tahoe	Body	Assist Step Controller																																																									
C	2013	Tahoe	Body	Body Control Module			V																													V			V																							
C	2013	Tahoe	Body	Body Control Module (aux.)																																																									
C	2013	Tahoe	Body	Digital Radio Receiver																																																									
C	2013	Tahoe	Body	Driver Door Switch																																																									
C	2013	Tahoe	Body	HVAC Control Module Auto																																																									
C	2013	Tahoe	Body	HVAC Control Module Manual																																																									
C	2013	Tahoe	Body	Instrument Panel Cluster																																																									
C	2013	Tahoe	Body	Left Side Object Detection Module																																																									
C	2013	Tahoe	Body	Lift Gate Module																																																									
C	2013	Tahoe	Body	Memory Seat Module																					V	V																																				
C	2013	Tahoe	Body	Navigation Radio																																																									
C	2013	Tahoe	Body	Park Assist Module																																																									
C	2013	Tahoe	Body	Passenger Door Switch																																																									
C	2013	Tahoe	Body	Passenger Presence System																																																									
C	2013	Tahoe	Body	Radio																																																									
C	2013	Tahoe	Body	Rear Heated Seat Module																																																									
C	2013	Tahoe	Body	Rear HVAC/RSA																																																									
C	2013	Tahoe	Body	Right Side Object Detection Module																																																									
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																									
C	2013	Tahoe	Body	Theft Deterrent Module		V																																																							
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V				
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
C	2013	Tahoe Hybrid	Body	Body Control Module			V																													V			V																							
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2013	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2013	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2013	Tahoe Hybrid	Body	Navigation Radio																																																										
C	2013	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2013	Tahoe Hybrid	Body	Radio																																																										
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module		V																																																								
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
C	2014	Captiva (3GN)	Body	Body Control Module																																																										
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Captiva (3GN)	Body	Passenger Presence Module																																																										
C	2014	Captiva (3GN)	Body	Instrument Cluster																																																										
C	2014	Captiva (3GN)	Body	Radio																																																										
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Captiva (3GN)	Body	HVAC Control Module																																																										
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																										
C	2014	Captiva (3GN)	Body	Theft Deterrent Module		V																																																								
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																										
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Captiva (Other)	Body	Instrument Cluster																																																										
C	2014	Captiva (Other)	Body	Headlamp Control Module																																																										
C	2014	Captiva (Other)	Body	HVAC Control Module																																																										
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																										V																
C	2014	Captiva (Other)	Body	Theft Deterrent Module		V																																																								
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																										
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																										
C	2014	Cheyenne	Chassis	Power Steering Control Module																																																										
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Cheyenne	Body	Body Control Module																																																										
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Cheyenne	Body	Passenger Presence Module																																																										
C	2014	Cheyenne	Body	Instrument Cluster																																																										
C	2014	Cheyenne	Body	Radio Control																																																										
C	2014	Cheyenne	Body	HVAC Control																																																										
C	2014	Cheyenne	Body	Radio																																																										
C	2014	Cheyenne	Body	Amplifier																																																										
C	2014	Cheyenne	Body	Media Disc Player																																																										
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																										
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
C	2014	Cheyenne	Body	HVAC Control Module																																																										
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																										
C	2014	Cheyenne	Body	Parking Assist Control Module																																																										
C	2014	Cheyenne	Body	Frontview Camera Module																																																										
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado	Chassis	Parking Brake Control Module																																																										
C	2014	Silverado	Chassis	Power Steering Control Module																																																										
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Silverado	Body	Body Control Module																																																										
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado	Body	Passenger Presence Module																																																										
C	2014	Silverado	Body	Instrument Cluster																																																										
C	2014	Silverado	Body	Radio Control																																																										
C	2014	Silverado	Body	HVAC Control																																																										
C	2014	Silverado	Body	Radio																																																										
C	2014	Silverado	Body	Amplifier																																																										
C	2014	Silverado	Body	Media Disc Player																																																										
C	2014	Silverado	Body	Human Machine Interface Control Module																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2014	Silverado	Body	Parking Assist Control Module																																																										
C	2014	Silverado	Body	Frontview Camera Module																																																										
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																										
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Suspension Control Module																																																										
C	2014	Silverado HD	Body	Body Control Module																																																										
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado HD	Body	Passenger Presence Module																																																										
C	2014	Silverado HD	Body	Instrument Cluster																																																										
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
C	2014	Silverado HD	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2014	Silverado HD	Body	Navigation Radio																																																										
C	2014	Silverado HD	Body	Uplevel Radio																																																										
C	2014	Silverado HD	Body	Amplifier																																																										
C	2014	Silverado HD	Body	Rear Audio Control Module																																																										
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																										
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																										
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Silverado HD	Body	Seat Memory Control Module																																																										
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																										
C	2014	Silverado HD	Body	Parking Assist Control Module																																																										
C	2014	Silverado HD	Body	Theft Deterrent Module		V																																																								
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																										
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2014	Suburban	Chassis	Parking Brake Control Module																																																										
C	2014	Suburban	Chassis	Suspension Control Module																																																										
C	2014	Suburban	Body	Body Control Module																																																										
C	2014	Suburban	Body	Auxiliary Body Control Module																																																										
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Suburban	Body	Passenger Presence Module																																																										
C	2014	Suburban	Body	Instrument Cluster																																																										
C	2014	Suburban	Body	Base Radio																																																										
C	2014	Suburban	Body	Navigation Radio																																																										
C	2014	Suburban	Body	Uplevel Radio																																																										
C	2014	Suburban	Body	Amplifier																																																										
C	2014	Suburban	Body	Rear Audio Control Module																																																										
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																										
C	2014	Suburban	Body	Personal Audio Link Control Module																																																										
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Suburban	Body	Liftgate Control Module																																																										
C	2014	Suburban	Body	Seat Memory Control Module																																																										
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2014	Suburban	Body	Assist Step Control Module																																																								
C	2014	Suburban	Body	Right Side Object Detection Control Module																																																								
C	2014	Suburban	Body	Left Side Object Detection Control Module																																																								
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																								
C	2014	Suburban	Body	Parking Assist Control Module																																																								
C	2014	Suburban	Body	Theft Deterrent Module		V																																																						
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																								
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																								
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																								
C	2014	Tahoe	Chassis	Suspension Control Module																																																								
C	2014	Tahoe	Body	Body Control Module																																																								
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																								
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Tahoe	Body	Passenger Presence Module																																																								
C	2014	Tahoe	Body	Instrument Cluster																																																								
C	2014	Tahoe	Body	Base Radio																																																								
C	2014	Tahoe	Body	Navigation Radio																																																								
C	2014	Tahoe	Body	Uplevel Radio																																																								
C	2014	Tahoe	Body	Amplifier																																																								
C	2014	Tahoe	Body	Rear Audio Control Module																																																								
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																								
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																								
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																								
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																								
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																								
C	2014	Tahoe	Body	Liftgate Control Module																																																								
C	2014	Tahoe	Body	Seat Memory Control Module																																																								
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																																								
C	2014	Tahoe	Body	Assist Step Control Module																																																								
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																																								
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																																								
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																								
C	2014	Tahoe	Body	Parking Assist Control Module																																																								
C	2014	Tahoe	Body	Theft Deterrent Module		V																																																						
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																								
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																								
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																								
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2015	Captiva (3GN)	Body	Body Control Module																																																												
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																																												
C	2015	Captiva (3GN)	Body	Instrument Cluster																																																												
C	2015	Captiva (3GN)	Body	Radio																																																												
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																												
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																												
C	2015	Captiva (3GN)	Body	HVAC Control Module																																																												
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																												
C	2015	Captiva (3GN)	Body	Theft Deterrent Module		V																																																										
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																												
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																												
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																												
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																												
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																												
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																												
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																												
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																												
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																												
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																												
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Captiva (Other)	Body	Instrument Cluster																																																												
C	2015	Captiva (Other)	Body	Headlamp Control Module																																																												
C	2015	Captiva (Other)	Body	HVAC Control Module																																																												
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																										V																		
C	2015	Captiva (Other)	Body	Theft Deterrent Module		V																																																										
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																												
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																										
C	2015	Cheyenne	Chassis	Power Steering Control Module																																																										
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Cheyenne	Chassis	Suspension Control Module																																																										
C	2015	Cheyenne	Body	Body Control Module																																																										
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Cheyenne	Body	Passenger Presence Module																																																										
C	2015	Cheyenne	Body	Instrument Cluster																																																										
C	2015	Cheyenne	Body	Radio Controls																																																										
C	2015	Cheyenne	Body	HVAC Controls																																																										
C	2015	Cheyenne	Body	Radio																																																										
C	2015	Cheyenne	Body	Amplifier																																																										
C	2015	Cheyenne	Body	Media Disc Player																																																										
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																										
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
C	2015	Cheyenne	Body	HVAC Control Module																																																										
C	2015	Cheyenne	Body	Parking Assist Control Module																																																										
C	2015	Cheyenne	Body	Frontview Camera Module																																																										
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Silverado	Chassis	Power Steering Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Silverado	Chassis	Suspension Control Module																																																											
C	2015	Silverado	Body	Body Control Module																																																										
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Silverado	Body	Passenger Presence Module																																																										
C	2015	Silverado	Body	Instrument Cluster																																																										
C	2015	Silverado	Body	Radio Controls																																																										
C	2015	Silverado	Body	HVAC Controls																																																										
C	2015	Silverado	Body	Radio																																																										
C	2015	Silverado	Body	Amplifier																																																										
C	2015	Silverado	Body	Media Disc Player																																																										
C	2015	Silverado	Body	Human Machine Interface Control Module																																																										
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																										
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2015	Silverado	Body	Parking Assist Control Module																																																										
C	2015	Silverado	Body	Frontview Camera Module																																																										
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Suburban	Chassis	Parking Brake Control Module																																																										
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Suburban	Chassis	Power Steering Control Module																																																										
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Suburban	Chassis	Suspension Control Module																																																										
C	2015	Suburban	Body	Body Control Module																																																										
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Suburban	Body	Passenger Presence Module																																																										
C	2015	Suburban	Body	Instrument Cluster																																																										
C	2015	Suburban	Body	Radio Controls																																																										
C	2015	Suburban	Body	HVAC Controls																																																										
C	2015	Suburban	Body	Radio																																																										
C	2015	Suburban	Body	Amplifier																																																										
C	2015	Suburban	Body	Media Disc Player																																																										
C	2015	Suburban	Body	Human Machine Interface Control Module																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Suburban	Body	HVAC Control Module																																																										
C	2015	Suburban	Body	Liftgate Control Module																																																										
C	2015	Suburban	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2015	Suburban	Body	Assist Step Control Module																																																									
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																										
C	2015	Suburban	Body	Parking Assist Control Module																																																										
C	2015	Suburban	Body	Frontview Camera Module																																																										
C	2015	Suburban	Body	Steering Column Lock Control Module																																																										
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																										
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																										
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																										
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Tahoe	Chassis	Power Steering Control Module																																																										
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Tahoe	Chassis	Suspension Control Module																																																										
C	2015	Tahoe	Body	Body Control Module																																																										
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Tahoe	Body	Passenger Presence Module																																																										
C	2015	Tahoe	Body	Instrument Cluster																																																										
C	2015	Tahoe	Body	Radio Controls																																																										
C	2015	Tahoe	Body	HVAC Controls																																																										
C	2015	Tahoe	Body	Radio																																																										
C	2015	Tahoe	Body	Amplifier																																																										
C	2015	Tahoe	Body	Media Disc Player																																																										
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																										
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																										
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Tahoe	Body	HVAC Control Module																																																										
C	2015	Tahoe	Body	Liftgate Control Module																																																										
C	2015	Tahoe	Body	Keyless Entry Control Module																																																										
C	2015	Tahoe	Body	Assist Step Control Module																																																										
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																										
C	2015	Tahoe	Body	Parking Assist Control Module																																																										
C	2015	Tahoe	Body	Frontview Camera Module																																																										
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																										
C	2015	Tahoe	Body	Battery Energy Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
C	2016	Captiva (3GN)	Body	Body Control Module																																																										
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																										
C	2016	Captiva (3GN)	Body	Radio																																																										
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																										
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																										
C	2016	Captiva (3GN)	Body	Theft Deterrent Module		V																																																								
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																										
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																										
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Captiva (Other)	Body	Instrument Cluster																																																										
C	2016	Captiva (Other)	Body	Headlamp Control Module																																																										
C	2016	Captiva (Other)	Body	Radio																																																										
C	2016	Captiva (Other)	Body	HVAC Control Module																																																										
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																										
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																										
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																									V																	
C	2016	Captiva (Other)	Body	Theft Deterrent Module		V																																																								
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																									
C	2016	Cheyenne	Chassis	Power Steering Control Module																																																									
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2016	Cheyenne	Chassis	Suspension Control Module																																																									
C	2016	Cheyenne	Body	Body Control Module																																																									
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Cheyenne	Body	Passenger Presence Module																																																									
C	2016	Cheyenne	Body	Instrument Cluster																																																									
C	2016	Cheyenne	Body	Radio Controls																																																									
C	2016	Cheyenne	Body	HVAC Controls																																																									
C	2016	Cheyenne	Body	Radio																																																									
C	2016	Cheyenne	Body	Amplifier																																																									
C	2016	Cheyenne	Body	Media Disc Player																																																									
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																									
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																									
C	2016	Cheyenne	Body	HVAC Control Module																																																									
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																									
C	2016	Cheyenne	Body	Parking Assist Control Module																																																									
C	2016	Cheyenne	Body	Frontview Camera Module																																																									
C	2016	Cheyenne	Body	Frontview Camera Module																																																									
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																									
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																									
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																									
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																									
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																									
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																									
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																									
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2016	Silverado	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2016	Silverado	Chassis	Power Steering Control Module																																																										
C	2016	Silverado	Chassis	Power Steering Control Module																																																										
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Silverado	Chassis	Suspension Control Module																																																										
C	2016	Silverado	Body	Body Control Module																																																										
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Silverado	Body	Passenger Presence Module																																																										
C	2016	Silverado	Body	Instrument Cluster																																																										
C	2016	Silverado	Body	Radio Controls																																																										
C	2016	Silverado	Body	HVAC Controls																																																										
C	2016	Silverado	Body	Radio (IO3)																																																										
C	2016	Silverado	Body	Radio (IOB)																																																										
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
C	2016	Silverado	Body	Amplifier																																																										
C	2016	Silverado	Body	Media Disc Player																																																										
C	2016	Silverado	Body	Human Machine Interface Control Module																																																										
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																										
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																										
C	2016	Silverado	Body	Parking Assist Control Module																																																										
C	2016	Silverado	Body	Frontview Camera Module																																																										
C	2016	Silverado	Body	Frontview Camera Module																																																										
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
C	2016	Suburban	Chassis	Parking Brake Control Module																																																										
C	2016	Suburban	Chassis	Power Steering Control Module																																																										
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Suburban	Chassis	Suspension Control Module																																																										
C	2016	Suburban	Body	Body Control Module																																																										
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Suburban	Body	Passenger Presence Module																																																										
C	2016	Suburban	Body	Instrument Cluster																																																										
C	2016	Suburban	Body	Radio Controls																																																										
C	2016	Suburban	Body	HVAC Controls																																																										
C	2016	Suburban	Body	Radio																																																										
C	2016	Suburban	Body	Amplifier																																																										
C	2016	Suburban	Body	Media Disc Player																																																										
C	2016	Suburban	Body	Human Machine Interface Control Module																																																										
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																																										
C	2016	Suburban	Body	HVAC Control Module																																																										
C	2016	Suburban	Body	Liftgate Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																										
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																										
C	2016	Suburban	Body	Keyless Entry Control Module																																																										
C	2016	Suburban	Body	Assist Step Control Module																																																										
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																										
C	2016	Suburban	Body	Parking Assist Control Module																																																										
C	2016	Suburban	Body	Frontview Camera Module																																																										
C	2016	Suburban	Body	Steering Column Lock Control Module																																																										
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																										
C	2016	Tahoe	Chassis	Power Steering Control Module																																																										
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Tahoe	Chassis	Suspension Control Module																																																										
C	2016	Tahoe	Body	Body Control Module																																																										
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Tahoe	Body	Passenger Presence Module																																																										
C	2016	Tahoe	Body	Instrument Cluster																																																										
C	2016	Tahoe	Body	Radio Controls																																																										
C	2016	Tahoe	Body	HVAC Controls																																																										
C	2016	Tahoe	Body	Radio																																																										
C	2016	Tahoe	Body	Amplifier																																																										
C	2016	Tahoe	Body	Media Disc Player																																																										
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																										
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																										
C	2016	Tahoe	Body	HVAC Control Module																																																										
C	2016	Tahoe	Body	Liftgate Control Module																																																										
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																										
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																										
C	2016	Tahoe	Body	Keyless Entry Control Module																																																										
C	2016	Tahoe	Body	Assist Step Control Module																																																										
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																										
C	2016	Tahoe	Body	Parking Assist Control Module																																																										
C	2016	Tahoe	Body	Frontview Camera Module																																																										
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																										
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																										
E	2004	ALL	Chassis	Electronic Brake Control Module																																																										
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2006	ALL	Chassis	Electronic Brake Control Module																																																										
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2007	ALL	Chassis	Electronic Brake Control Module																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM				V	V																																																					
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM				V	V																																																					
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module				V	V																																																					
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module				V	V																																																					
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																					
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																									
G	2004	Express/Savana	Body	Body Control Module																																																									
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2004	Express/Savana	Body	OnStar																																																V	V							
G	2004	Express/Savana	Body	Base Radio																																																									
G	2004	Express/Savana	Body	Uplevel Radio																																																									
G	2004	Express/Savana	Body	Remote Function Actuation																																																									
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM				V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM				V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																				
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module				V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																																V	V							
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																						
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control				V	V																																																					
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module			V	V	V																																																					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																					
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																					
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																					
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2005	Express/Savana	Chassis	VSES																																																									
G	2005	Express/Savana	Body	Body Control Module																																																									
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2005	Express/Savana	Body	Base Radio																																																									
G	2005	Express/Savana	Body	Uplevel Radio																																																									
G	2005	Express/Savana	Body	Remote Function Actuation																																																									
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																V	V								
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control				V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module			V	V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2005	Express Access/Savana Pro	Chassis	VSES																																																										
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2005	Express Access/Savana Pro	Body	Base Radio																																																										
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																V	V								
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control				V	V																																																					
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																					
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																					
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																					
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2006	Express/Savana	Chassis	VSES																																																										
G	2006	Express/Savana	Body	Body Control Module																																																										
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2006	Express/Savana	Body	Passenger Presence System																																																										
G	2006	Express/Savana	Body	Base Radio																																																										
G	2006	Express/Savana	Body	Uplevel Radio																																																										
G	2006	Express/Savana	Body	Remote Function Actuation																																																										
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint	V																																																									
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																V	V	V							
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control				V	V																																																					
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																					
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																					
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																					
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																											
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																											
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																											
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2006	Express Access/Savana Pro	Chassis	VSES																																																										
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2006	Express Access/Savana Pro	Body	Base Radio																																																										
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																															V	V	V					
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																		
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control				V	V																																																			
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control			V	V	V																																																		
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																		
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																							
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																		
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																		
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																		
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																		
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																							
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																		
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																							
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																							
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																							
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																															V		
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																							
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																							
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																							
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2007	Express/Savana	Body	Body Control Module																																																							
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																							
G	2007	Express/Savana	Body	Passenger Presence System																																																							
G	2007	Express/Savana	Body	Base Radio																																																							
G	2007	Express/Savana	Body	Uplevel Radio																																																							
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint	V																																																						
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																V	V	V					
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																		
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control				V	V																																																		
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control			V	V	V																																																		
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																		
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																							
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																		
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																		
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																		
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																		

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																				
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																	V		
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																									
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2007	Express Access/Savana Pro	Body	Radio																																																									
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V																																																								
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																															V	V	V						
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																				
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																				
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																				
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																V				
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																												
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																												
G	2008	Express/Savana	Body	Body Control Module			V																																																						
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2008	Express/Savana	Body	Passenger Presence System																																																										
G	2008	Express/Savana	Body	Radio																																																									
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express/Savana	Body	Rollover Sensor																																																										
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																							
G	2008	Express/Savana	Body	Theft Deterrent Module		V																																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																				
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																				
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																				
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																				

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																V			
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																											
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																											
G	2008	Express Access/Savana Pro	Body	Body Control Module			V																																																							
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2008	Express Access/Savana Pro	Body	Radio																																																									
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																						
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																							
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																				
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																				
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																				
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																															V			V
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																															V			
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																												
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																												
G	2009	Express/Savana	Body	Body Control Module			V																																																						
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2009	Express/Savana	Body	Passenger Presence System																																																										
G	2009	Express/Savana	Body	Radio																																																									
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express/Savana	Body	Rollover Sensor																																																										
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																						
G	2009	Express/Savana	Body	Theft Deterrent Module		V																																																								
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																				
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																				
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																				
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																															V			V
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																															V			
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																													
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																													
G	2009	Express Access/Savana Pro	Body	Body Control Module			V																																																								
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2009	Express Access/Savana Pro	Body	Radio																																																											
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																								
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																									
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V			V
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V						
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V						
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V						
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																															V						
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																															V						
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																														
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																														
G	2010	Express/Savana	Body	Body Control Module			V																																																								
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2010	Express/Savana	Body	Passenger Presence System																																																												
G	2010	Express/Savana	Body	Radio																																																											
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2010	Express/Savana	Body	Rollover Sensor																																																												
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																								
G	2010	Express/Savana	Body	Theft Deterrent Module		V																																																										
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V			V
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V						
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V						
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V						
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																															V						
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																															V			
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																							
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																							
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																										
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																										
G	2010	Express Access/Savana Pro	Body	Body Control Module			V																																																					
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																							
G	2010	Express Access/Savana Pro	Body	Radio																																																							
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																							
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																				
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																						
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V			V
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V			
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V			
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V			
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																															V			V
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																							
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																															V			
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																							
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																							
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																										
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																										
G	2011	Express/Savana	Body	Body Control Module			V																																																				
G	2011	Express/Savana	Body	Digital Radio Receiver																																																							
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2011	Express/Savana	Body	Passenger Presence System																																																							
G	2011	Express/Savana	Body	Radio																																																							
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
G	2011	Express/Savana	Body	Rollover Sensor																																																							
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																				
G	2011	Express/Savana	Body	Theft Deterrent Module		V																																																						
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V			V
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V			
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V			
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V			
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																															V			V
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																															V			
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																							
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																							
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																										
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																										
G	2011	Express Access/Savana Pro	Body	Body Control Module			V																																																					
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																							
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																							
G	2011	Express Access/Savana Pro	Body	Radio																																																							
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																							
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																				
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																						
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V			V
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V			
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V			
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V			
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																															V			V
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																							
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																															V			
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																							
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																							
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																										
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																										
G	2012	Express/Savana	Body	Body Control Module			V																															V																					
G	2012	Express/Savana	Body	Digital Radio Receiver																																																							
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2012	Express/Savana	Body	Passenger Presence System																																																							
G	2012	Express/Savana	Body	Radio																																																							
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
G	2012	Express/Savana	Body	Rollover Sensor																																																							
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																					
G	2012	Express/Savana	Body	Theft Deterrent Module		V																																																						
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V			V
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V			
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V			
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V			
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																															V			V
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																													V			
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																						
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																									
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																									
G	2012	Express Access/Savana Pro	Body	Body Control Module			V																																V																				
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																						
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																						
G	2012	Express Access/Savana Pro	Body	Radio																																																						
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																						
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																			
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																				
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																													V			V
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																					
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																													V			
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																					
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																													V			
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																						
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																													V			
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																						
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																													V			V
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																						
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																													V			
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																						
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																									
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																									
G	2013	Express/Savana	Body	Body Control Module			V																																V																				
G	2013	Express/Savana	Body	Digital Radio Receiver																																																						
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																						
G	2013	Express/Savana	Body	Navigation Radio																																																						
G	2013	Express/Savana	Body	Park Assist Module																																																						
G	2013	Express/Savana	Body	Passenger Presence System																																																						
G	2013	Express/Savana	Body	Radio																																																						
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
G	2013	Express/Savana	Body	Rollover Sensor																																																						
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																			
G	2013	Express/Savana	Body	Theft Deterrent Module		V																																																				
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																													V			V
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																					
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																													V			
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																					
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																													V			
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																					
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																					
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																													V			

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																														V			V
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																						
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																														V			
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																						
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																									
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																									
G	2013	Express Access/Savana Pro	Body	Body Control Module			V																																V																				
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																						
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																						
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																						
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																						
G	2013	Express Access/Savana Pro	Body	Radio																																																						
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																						
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																				
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																					
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																						
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																						
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																						
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																						
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																						
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																						
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																						
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																						
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																						
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																						
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																						
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																						
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																						
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																						
G	2014	Express	Chassis	Electronic Brake Control Module																																																						
G	2014	Express	Body	Body Control Module																																																						
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																			V																																				
G	2014	Express	Body	Passenger Presence Module																																																						
G	2014	Express	Body	Rollover Sensor Module																																																						
G	2014	Express	Body	Instrument Cluster																																																						
G	2014	Express	Body	Chime Alarm Control Module																																																						
G	2014	Express	Body	Base Radio																																																						
G	2014	Express	Body	Navigation Radio																																																						
G	2014	Express	Body	Uplevel Radio																																																						
G	2014	Express	Body	Digital Radio Receiver Control Module																																																						
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																						
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																						
G	2014	Express	Body	Auxiliary Heater Control Module																																																						
G	2014	Express	Body	Remote Control Door Lock Receiver																																																						
G	2014	Express	Body	Parking Assist Control Module																																																						
G	2014	Express	Body	Theft Deterrent Module		V																																																				

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2014	Savana	Chassis	Electronic Brake Control Module																																																										
G	2014	Savana	Body	Body Control Module																																																									
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																			V																																							
G	2014	Savana	Body	Passenger Presence Module																																																										
G	2014	Savana	Body	Rollover Sensor Module																																																										
G	2014	Savana	Body	Instrument Cluster																																																										
G	2014	Savana	Body	Chime Alarm Control Module																																																										
G	2014	Savana	Body	Base Radio																																																										
G	2014	Savana	Body	Navigation Radio																																																										
G	2014	Savana	Body	Uplevel Radio																																																										
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2014	Savana	Body	Auxiliary Heater Control Module																																																										
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
G	2014	Savana	Body	Parking Assist Control Module																																																										
G	2014	Savana	Body	Theft Deterrent Module		V																																																								
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2015	Express	Chassis	Electronic Brake Control Module																																																										
G	2015	Express	Body	Body Control Module																																																									
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																			V																																							
G	2015	Express	Body	Rollover Sensor Module																																																										
G	2015	Express	Body	Instrument Cluster																																																										
G	2015	Express	Body	Digital Radio Receiver Control Module																																																										
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2015	Express	Body	Auxiliary Heater Control Module																																																										
G	2015	Express	Body	Remote Control Door Lock Receiver																																																										
G	2015	Express	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2015	Express	Body	Theft Deterrent Module		V																																																								
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2015	Savana	Chassis	Electronic Brake Control Module																																																										
G	2015	Savana	Body	Body Control Module																																																									
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																			V																																							
G	2015	Savana	Body	Rollover Sensor Module																																																										
G	2015	Savana	Body	Instrument Cluster																																																									
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2015	Savana	Body	Auxiliary Heater Control Module																																																										
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
G	2015	Savana	Body	Parking Assist Control Module																																																										
G	2015	Savana	Body	Theft Deterrent Module		V																																																								
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2016	Express	Chassis	Electronic Brake Control Module																																																										
G	2016	Express	Body	Body Control Module																																																									
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2016	Express	Body	Instrument Cluster																																																									
G	2016	Express	Body	Chime Alarm Control Module																																																									
G	2016	Express	Body	Base Radio																																																									
G	2016	Express	Body	Navigation Radio																																																									
G	2016	Express	Body	Uplevel Radio																																																									
G	2016	Express	Body	Digital Radio Receiver Control Module																																																										
G	2016	Express	Body	Telematics Communication Interface Control Module																																																										
G	2016	Express	Body	Auxiliary Heater Control Module																																																										
G	2016	Express	Body	Remote Control Door Lock Receiver																																																										
G	2016	Express	Body	Parking Assist Control Module																																																										
G	2016	Express	Body	Theft Deterrent Module		V																																																								
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2016	Savana	Chassis	Electronic Brake Control Module																																																										
G	2016	Savana	Body	Body Control Module																																																									
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
G	2016	Savana	Body	Instrument Cluster																																																									
G	2016	Savana	Body	Chime Alarm Control Module																																																									
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																									
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																									
G	2016	Savana	Body	Auxiliary Heater Control Module																																																									
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																									
G	2016	Savana	Body	Parking Assist Control Module																																																									
G	2016	Savana	Body	Theft Deterrent Module		V																																																							
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module				V	V																																																				
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2004	Express/Savana	Chassis	VSES																																																									
H	2004	Express/Savana	Body	Body Control Module																																																									
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2004	Express/Savana	Body	OnStar																																																V	V								
H	2004	Express/Savana	Body	Base Radio																																																									
H	2004	Express/Savana	Body	Uplevel Radio																																																									
H	2004	Express/Savana	Body	Remote Function Actuation																																																									
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module				V	V																																																				
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
H	2004	Express Access/Savana Pro	Chassis	VSES																																																									
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2004	Express Access/Savana Pro	Body	OnStar																																																V	V								
H	2004	Express Access/Savana Pro	Body	Base Radio																																																									
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																				
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																			
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2005	Express/Savana	Chassis	VSES																																																									
H	2005	Express/Savana	Body	Body Control Module																																																									
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2005	Express/Savana	Body	Base Radio																																																									
H	2005	Express/Savana	Body	Uplevel Radio																																																									
H	2005	Express/Savana	Body	Remote Function Actuation																																																									
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																V	V						
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																		
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																							
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																	
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																						
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																						
H	2005	Express Access/Savana Pro	Chassis	VSES																																																						
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																						
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																						
H	2005	Express Access/Savana Pro	Body	Base Radio																																																						
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																						
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																						
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																						
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																V	V						
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																		
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																							
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																	
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																						
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																						
H	2006	Express/Savana	Chassis	VSES																																																						
H	2006	Express/Savana	Body	Body Control Module																																																						
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																						
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																						
H	2006	Express/Savana	Body	Passenger Presence System																																																						
H	2006	Express/Savana	Body	Base Radio																																																						
H	2006	Express/Savana	Body	Uplevel Radio																																																						
H	2006	Express/Savana	Body	Remote Function Actuation																																																						
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint	V																																																					
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																															V	V	V						
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																		
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																						
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																	
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																						
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																						
H	2006	Express Access/Savana Pro	Chassis	VSES																																																						
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																						
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																						
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																						
H	2006	Express Access/Savana Pro	Body	Base Radio																																																						
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																						
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																						
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V																																																				
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																															V	V	V						
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																	
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																						
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																	
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																						
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																	
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express/Savana	Body	Body Control Module																																																										
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2007	Express/Savana	Body	Passenger Presence System																																																										
H	2007	Express/Savana	Body	Base Radio																																																										
H	2007	Express/Savana	Body	Uplevel Radio																																																										
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint	V																																																									
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																V	V	V								
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																					
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																					
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																					
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2007	Express Access/Savana Pro	Body	Base Radio																																																										
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V																																																									
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																V	V	V								
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																					
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																					
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																													
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																													
H	2008	Express/Savana	Body	Body Control Module			V																																																							
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2008	Express/Savana	Body	Passenger Presence System																																																										
H	2008	Express/Savana	Body	Radio																																																										
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express/Savana	Body	Rollover Sensor																																																										
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																							
H	2008	Express/Savana	Body	Theft Deterrent Module		V																																																								
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																					
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																				
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																				
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																											
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																											
H	2008	Express Access/Savana Pro	Body	Body Control Module			V																																																							
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																							
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																								
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																					
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																					
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																															V			V
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																													
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																													
H	2009	Express/Savana	Body	Body Control Module			V																																																							
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2009	Express/Savana	Body	Passenger Presence System																																																											
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
H	2009	Express/Savana	Body	Rollover Sensor																																																											
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																							
H	2009	Express/Savana	Body	Theft Deterrent Module		V																																																									
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																					
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																					
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																															V			V
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																													
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																														
H	2009	Express Access/Savana Pro	Body	Body Control Module			V																																																							
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																											
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																						
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																							
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V				
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V				
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V				
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																												
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																												
H	2010	Express/Savana	Body	Body Control Module			V																																																						
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2010	Express/Savana	Body	Passenger Presence System																																																										
H	2010	Express/Savana	Body	Radio																																																									
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2010	Express/Savana	Body	Rollover Sensor																																																									
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																						
H	2010	Express/Savana	Body	Theft Deterrent Module		V																																																							
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V				
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V				
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V				
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																												
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																												
H	2010	Express Access/Savana Pro	Body	Body Control Module			V																																																						
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2010	Express Access/Savana Pro	Body	Radio																																																									
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																						
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																							
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V				
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V				
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V				
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																															V				V
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																												
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																												
H	2011	Express/Savana	Body	Body Control Module			V																																																						
H	2011	Express/Savana	Body	Digital Radio Receiver																																																										
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2011	Express/Savana	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2011	Express/Savana	Body	Radio																																																								
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2011	Express/Savana	Body	Rollover Sensor																																																								
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																					
H	2011	Express/Savana	Body	Theft Deterrent Module		V																																																						
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V				
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V				
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V				
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																															V			V	
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																											
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																											
H	2011	Express Access/Savana Pro	Body	Body Control Module			V																																																					
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2011	Express Access/Savana Pro	Body	Radio																																																								
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																					
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																						
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V				
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V				
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V				
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																															V			V	
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																											
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																											
H	2012	Express/Savana	Body	Body Control Module			V																																V																					
H	2012	Express/Savana	Body	Digital Radio Receiver																																																								
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2012	Express/Savana	Body	Passenger Presence System																																																								
H	2012	Express/Savana	Body	Radio																																																								
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2012	Express/Savana	Body	Rollover Sensor																																																								
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																					
H	2012	Express/Savana	Body	Theft Deterrent Module		V																																																						
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V				
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V				
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V				

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																														V			V
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																						
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																										
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																										
H	2012	Express Access/Savana Pro	Body	Body Control Module			V																																V																					
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																							
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
H	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																							
H	2012	Express Access/Savana Pro	Body	Radio																																																							
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
H	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																							
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																				
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																					
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																														V				
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																														V				
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																														V				
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																														V			V
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																										
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																										
H	2013	Express/Savana	Body	Body Control Module			V																																V																					
H	2013	Express/Savana	Body	Digital Radio Receiver																																																							
H	2013	Express/Savana	Body	Instrument Panel Cluster																																																							
H	2013	Express/Savana	Body	Navigation Radio																																																							
H	2013	Express/Savana	Body	Park Assist Module																																																							
H	2013	Express/Savana	Body	Passenger Presence System																																																							
H	2013	Express/Savana	Body	Radio																																																							
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
H	2013	Express/Savana	Body	Rollover Sensor																																																							
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																				
H	2013	Express/Savana	Body	Theft Deterrent Module		V																																																					
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																														V				
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																														V				
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																														V				
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																														V			V
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																										
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																										
H	2013	Express Access/Savana Pro	Body	Body Control Module			V																																V																					
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																							
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
H	2013	Express Access/Savana Pro	Body	Navigation Radio																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2013	Express Access/Savana Pro	Body	Radio																																																										
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																							
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																								
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2014	Express	Chassis	Electronic Brake Control Module																																																										
H	2014	Express	Body	Body Control Module																																																										
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																			V																																							
H	2014	Express	Body	Passenger Presence Module																																																										
H	2014	Express	Body	Rollover Sensor Module																																																										
H	2014	Express	Body	Instrument Cluster																																																										
H	2014	Express	Body	Chime Alarm Control Module																																																										
H	2014	Express	Body	Base Radio																																																										
H	2014	Express	Body	Navigation Radio																																																										
H	2014	Express	Body	Uplevel Radio																																																										
H	2014	Express	Body	Digital Radio Receiver Control Module																																																										
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2014	Express	Body	Auxiliary Heater Control Module																																																										
H	2014	Express	Body	Remote Control Door Lock Receiver																																																										
H	2014	Express	Body	Parking Assist Control Module																																																										
H	2014	Express	Body	Theft Deterrent Module		V																																																								
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2014	Savana	Chassis	Electronic Brake Control Module																																																											
H	2014	Savana	Body	Body Control Module																																																										
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																			V																																							
H	2014	Savana	Body	Passenger Presence Module																																																										
H	2014	Savana	Body	Rollover Sensor Module																																																										
H	2014	Savana	Body	Instrument Cluster																																																										
H	2014	Savana	Body	Chime Alarm Control Module																																																										
H	2014	Savana	Body	Base Radio																																																										
H	2014	Savana	Body	Navigation Radio																																																										
H	2014	Savana	Body	Uplevel Radio																																																										
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2014	Savana	Body	Auxiliary Heater Control Module																																																										
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2014	Savana	Body	Parking Assist Control Module																																																										
H	2014	Savana	Body	Theft Deterrent Module		V																																																								
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2015	Express	Chassis	Electronic Brake Control Module																																																										
H	2015	Express	Body	Body Control Module																																																										
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																			V																																							
H	2015	Express	Body	Rollover Sensor Module																																																										
H	2015	Express	Body	Instrument Cluster																																																										
H	2015	Express	Body	Digital Radio Receiver Control Module																																																										
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2015	Express	Body	Auxiliary Heater Control Module																																																										
H	2015	Express	Body	Remote Control Door Lock Receiver																																																										
H	2015	Express	Body	Parking Assist Control Module																																																										
H	2015	Express	Body	Theft Deterrent Module		V																																																								
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2015	Savana	Chassis	Electronic Brake Control Module																																																										
H	2015	Savana	Body	Body Control Module																																																										
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																			V																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2015	Savana	Body	Rollover Sensor Module																																																										
H	2015	Savana	Body	Instrument Cluster																																																										
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2015	Savana	Body	Auxiliary Heater Control Module																																																										
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2015	Savana	Body	Parking Assist Control Module																																																										
H	2015	Savana	Body	Theft Deterrent Module		V																																																								
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2016	Express	Chassis	Electronic Brake Control Module																																																										
H	2016	Express	Body	Body Control Module																																																										
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Express	Body	Instrument Cluster																																																										
H	2016	Express	Body	Chime Alarm Control Module																																																										
H	2016	Express	Body	Base Radio																																																										
H	2016	Express	Body	Navigation Radio																																																										
H	2016	Express	Body	Uplevel Radio																																																										
H	2016	Express	Body	Digital Radio Receiver Control Module																																																										
H	2016	Express	Body	Telematics Communication Interface Control Module																																																										
H	2016	Express	Body	Auxiliary Heater Control Module																																																										
H	2016	Express	Body	Remote Control Door Lock Receiver																																																										
H	2016	Express	Body	Parking Assist Control Module																																																										
H	2016	Express	Body	Theft Deterrent Module		V																																																								
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2016	Savana	Chassis	Electronic Brake Control Module																																																										
H	2016	Savana	Body	Body Control Module																																																										
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Savana	Body	Instrument Cluster																																																										
H	2016	Savana	Body	Chime Alarm Control Module																																																										
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
H	2016	Savana	Body	Auxiliary Heater Control Module																																																										
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2016	Savana	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2016	Savana	Body	Theft Deterrent Module		V																																																								
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																										
J	2004	ALL	Chassis	Electronic Brake Control Module																																																										
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
J	2007	ALL	Chassis	Electronic Brake Control Module																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								V		
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer					V																																																					
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer					V																																																					
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer					V																																																					
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer					V																																																					
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																										
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Tracker	Chassis	Power Steering Control Module																																																										
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Tracker	Body	Body Control Module																																																										
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Tracker	Body	Passenger Presence Module																																																										
J	2013	Tracker	Body	Instrument Cluster																																																										
J	2013	Tracker	Body	Radio																																																										
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																																										
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Tracker	Body	Front Seat Heating Control Module																																																										
J	2013	Tracker	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2013	Tracker	Body	Frontview Camera Module																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																					V				
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer					V																																																				
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer					V																																																				
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer					V																																																				
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer					V																																																				
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2013	Trax	Chassis	Electronic Brake Control Module																																																										
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Trax	Chassis	Power Steering Control Module																																																										
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Trax	Body	Body Control Module																																																										
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Trax	Body	Passenger Presence Module																																																										
J	2013	Trax	Body	Instrument Cluster																																																										
J	2013	Trax	Body	Radio																																																										
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Trax	Body	Front Seat Heating Control Module																																																										
J	2013	Trax	Body	Parking Assist Control Module																																																										
J	2013	Trax	Body	Frontview Camera Module																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission					V																																																					
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission					V																																																			V		
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																										
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								V		
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer					V																																																					
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer					V																																																					
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer					V																																																					
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer					V																																																					
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																										
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2014	Tracker	Chassis	Power Steering Control Module																																																										
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Tracker	Body	Body Control Module																																																										
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Tracker	Body	Passenger Presence Module																																																										
J	2014	Tracker	Body	Instrument Cluster																																																										
J	2014	Tracker	Body	Radio																																																										
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																																										
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Tracker	Body	Front Seat Heating Control Module																																																										
J	2014	Tracker	Body	Parking Assist Control Module																																																										
J	2014	Tracker	Body	Frontview Camera Module																																																										
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																						V		
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer					V																																																				
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer					V																																																				
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2014	Trax	Chassis	Electronic Brake Control Module																																																										
J	2014	Trax	Chassis	Power Steering Control Module																																																										
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Trax	Body	Body Control Module																																																										
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Trax	Body	Passenger Presence Module																																																										
J	2014	Trax	Body	Instrument Cluster																																																										
J	2014	Trax	Body	Radio																																																										
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Trax	Body	Front Seat Heating Control Module																																																										
J	2014	Trax	Body	Parking Assist Control Module																																																										
J	2014	Trax	Body	Frontview Camera Module																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																							V		
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer					V																																																				
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer					V																																																				
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer					V																																																				
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																									
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer					V																																																				
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																									
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																									
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																									
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																									
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																									
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																									
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																																									
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																									
J	2015	Tracker	Chassis	Power Steering Control Module																																																									
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2015	Tracker	Body	Body Control Module																																																									
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2015	Tracker	Body	Instrument Cluster																																																									
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																																									
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																																									
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																																									
J	2015	Tracker	Body	Front Seat Heating Control Module																																																									
J	2015	Tracker	Body	Parking Assist Control Module																																																									
J	2015	Tracker	Body	Frontview Camera Module																																																									
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																									
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																									
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																							V		
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																									
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission					V																																																				
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission					V																																																				
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																									
J	2015	Trax	Powertrain	Chassis Control Module																																																									
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																									
J	2015	Trax	Chassis	Electronic Brake Control Module																																																									
J	2015	Trax	Chassis	Power Steering Control Module																																																									
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2015	Trax	Body	Body Control Module																																																									
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2015	Trax	Body	Passenger Presence Module																																																									
J	2015	Trax	Body	Instrument Cluster																																																									
J	2015	Trax	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Trax	Body	Seat Memory Control Module																																																										
J	2015	Trax	Body	Front Seat Heating Control Module																																																										
J	2015	Trax	Body	Right Side Object Detection Control Module																																																										
J	2015	Trax	Body	Left Side Object Detection Control Module																																																										
J	2015	Trax	Body	Parking Assist Control Module																																																										
J	2015	Trax	Body	Frontview Camera Module																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer					V																																																					
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer					V																																																					
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																										
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2016	Tracker	Chassis	Power Steering Control Module																																																										
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Tracker	Body	Body Control Module																																																										
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Tracker	Body	Instrument Cluster																																																										
J	2016	Tracker	Body	Trailer Interface Control Module																																																										
J	2016	Tracker	Body	Radio																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Tracker	Body	Front Seat Heating Control Module																																																										
J	2016	Tracker	Body	Parking Assist Control Module																																																										
J	2016	Tracker	Body	Frontview Camera Module																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2016	Trax	Powertrain	Chassis Control Module																																																										
J	2016	Trax	Chassis	Electronic Brake Control Module																																																										
J	2016	Trax	Chassis	Power Steering Control Module																																																										
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Trax	Body	Body Control Module																																																										
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Trax	Body	Passenger Presence Module																																																										
J	2016	Trax	Body	Instrument Cluster																																																										
J	2016	Trax	Body	Trailer Interface Control Module																																																										
J	2016	Trax	Body	Radio																																																										
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Trax	Body	Seat Memory Control Module																																																										
J	2016	Trax	Body	Front Seat Heating Control Module																																																										
J	2016	Trax	Body	Right Side Object Detection Control Module																																																										
J	2016	Trax	Body	Left Side Object Detection Control Module																																																										
J	2016	Trax	Body	Parking Assist Control Module																																																										
J	2016	Trax	Body	Frontview Camera Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM			V	V	V																																																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM			V	V	V																																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM			V	V	V																																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																				
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																				
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																				
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module			V	V	V																																																					
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module				V	V																																																						
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																											
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module				V	V																																																						
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module					V																																																						
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																											
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																											
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																						
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																											
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module			V	V	V																																																						
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																											
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																											
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																											
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																											
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																											
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
K	2004	ALL	Chassis	ESC																																																										
K	2004	ALL	Chassis	Rear Wheel Steering																																																											
K	2004	ALL	Chassis	Tire Pressure Monitor																																																											
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																											
K	2004	ALL	Chassis	VSES																																																										
K	2004	ALL	Body	Amplifier (Bose)																																																											
K	2004	ALL	Body	Body Control Module																																																										
K	2004	ALL	Body	CD Changer																																																										
K	2004	ALL	Body	Chime																																																										
K	2004	ALL	Body	Driver Door Module																																																										
K	2004	ALL	Body	Driver Seat Module																			V																																							
K	2004	ALL	Body	Heating and Air Conditioning Auto																			V																																							
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																			V																																							
K	2004	ALL	Body	Instrument Panel Cluster																																																											
K	2004	ALL	Body	OnStar																																																V	V									
K	2004	ALL	Body	Passenger Door Module																																																										
K	2004	ALL	Body	Passenger Presence System																																																										
K	2004	ALL	Body	Radio Base																																																										
K	2004	ALL	Body	Radio Uplevel																																																										
K	2004	ALL	Body	Radio Navigation								V																																																	
K	2004	ALL	Body	Rear Aux. Climate Module																																																										
K	2004	ALL	Body	Rear HVAC																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2004	ALL	Body	Rear Seat Audio																																																										
K	2004	ALL	Body	Rear Seat Entertainment																																																										
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2004	ALL	Body	Vehicle Theft Deterrent		V																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM			V	V	V																																																					
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM			V	V	V																																																					
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM			V	V	V																																																					
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																					
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module			V	V	V																																																					
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																					
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module			V	V	V																																																					
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module				V	V																																																					
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module				V	V																																																					
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module			V	V	V																																																					
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																			V																																							
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																			V																																							
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																			V																																							
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio								V																																																		
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																															V	V										
K	2005	ALL	Body	Vehicle Theft Deterrent		V																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM			V	V	V																																																					
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM			V	V	V																																																					
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM			V	V	V																																																					
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																					
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module			V	V	V																																																					
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																					
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																											
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module			V	V	V																																																						
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module				V	V																																																						
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																											
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module				V	V																																																						
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																											
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																											
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module					V																																																						
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																											
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																											
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																						
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module			V	V	V																																																						
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																											
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																											
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																											
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																											
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																											
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
K	2006	ALL	Chassis	ESC																																																										
K	2006	ALL	Chassis	Tire Pressure Monitor																																																											
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																											
K	2006	ALL	Chassis	VSES																																																										
K	2006	ALL	Body	Amplifier (Bose)																																																											
K	2006	ALL	Body	Body Control Module																																																										
K	2006	ALL	Body	CD Changer																																																										
K	2006	ALL	Body	Chime																																																										
K	2006	ALL	Body	Disc Player and Video Display																																																											
K	2006	ALL	Body	Driver Door Module																																																										
K	2006	ALL	Body	Driver Seat Module																			V																																							
K	2006	ALL	Body	Generator Battery Control Module																																																											
K	2006	ALL	Body	Heating and Air Conditioning Auto																			V																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2006	ALL	Body	Heating and Air Conditioning Manual																			V																																							
K	2006	ALL	Body	Instrument Panel Cluster																																																										
K	2006	ALL	Body	Passenger Door Module																																																										
K	2006	ALL	Body	Passenger Presence System																																																										
K	2006	ALL	Body	Base Radio																																																										
K	2006	ALL	Body	Uplevel Radio																																																										
K	2006	ALL	Body	Navigation Radio								V																																																	
K	2006	ALL	Body	Rear Aux. Climate Module																																																										
K	2006	ALL	Body	Rear HVAC																																																										
K	2006	ALL	Body	Rear Seat Audio																																																										
K	2006	ALL	Body	Supplemental Inflatable Restraint	V																																																									
K	2006	ALL	Body	Vehicle Theft Deterrent		V																																																								
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																V	V	V							
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																						
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																						
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES													V																																													
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES													V																																													
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW													V																																													
K	2007	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																																											
K	2007	Avalanche	Body	Amplifier (Bose)																																																											
K	2007	Avalanche	Body	Assist Step Controller																																																											
K	2007	Avalanche	Body	Body Control Module			V																													V																											
K	2007	Avalanche	Body	Body Control Module (aux.)																																																											
K	2007	Avalanche	Body	Digital Radio Receiver																																																											
K	2007	Avalanche	Body	Driver Door Switch																																																											
K	2007	Avalanche	Body	HVAC Control Module Auto																																																											
K	2007	Avalanche	Body	HVAC Control Module Manual																																																											
K	2007	Avalanche	Body	Instrument Panel Cluster																																																											
K	2007	Avalanche	Body	Memory Seat Module																					V	V																																					
K	2007	Avalanche	Body	Park Assist Module																																																											
K	2007	Avalanche	Body	Passenger Door Switch																																																											
K	2007	Avalanche	Body	Passenger Presence System																																																											
K	2007	Avalanche	Body	Radio																																																										
K	2007	Avalanche	Body	Rear Heated Seat Module																																																											
K	2007	Avalanche	Body	Rear HVAC/RSA																																																											
K	2007	Avalanche	Body	Rollover Sensor																																																											
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																			V																																								
K	2007	Avalanche	Body	Theft Deterrent Module		V																																																									
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																				
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																				
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																				
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																				
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES													V																																												
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
K	2007	Suburban	Chassis	Electronic Suspension Control																																																									
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																									
K	2007	Suburban	Body	Amplifier (Bose)																																																									
K	2007	Suburban	Body	Assist Step Controller																																																									
K	2007	Suburban	Body	Body Control Module			V																													V																										
K	2007	Suburban	Body	Body Control Module (aux.)																																																									
K	2007	Suburban	Body	Digital Radio Receiver																																																									
K	2007	Suburban	Body	Driver Door Switch																																																									
K	2007	Suburban	Body	HVAC Control Module Auto																																																									
K	2007	Suburban	Body	HVAC Control Module Manual																																																									
K	2007	Suburban	Body	Instrument Panel Cluster																																																									
K	2007	Suburban	Body	Lift Gate Module																																																									
K	2007	Suburban	Body	Memory Seat Module																					V	V																																			
K	2007	Suburban	Body	Park Assist Module																																																									
K	2007	Suburban	Body	Passenger Door Switch																																																									
K	2007	Suburban	Body	Passenger Presence System																																																									
K	2007	Suburban	Body	Radio																																																									
K	2007	Suburban	Body	Rear Heated Seat Module																																																									
K	2007	Suburban	Body	Rear HVAC/RSA																																																									
K	2007	Suburban	Body	Rollover Sensor																																																									
K	2007	Suburban	Body	Supplemental Inflatable Restraint																			V																																						
K	2007	Suburban	Body	Theft Deterrent Module		V																																																							
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																				
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																				
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																				
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																				
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																					
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																					
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																					
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																													
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																													
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW													V																																													
K	2007	Silverado	Chassis	Electronic Suspension Control																																																										
K	2007	Silverado	Chassis	Trailer Brake Control Module																																																										
K	2007	Silverado	Body	Amplifier (Bose)																																																										
K	2007	Silverado	Body	Body Control Module			V																													V																										
K	2007	Silverado	Body	Body Control Module (aux.)																																																										
K	2007	Silverado	Body	Digital Radio Receiver																																																										
K	2007	Silverado	Body	Driver Door Switch																																																										
K	2007	Silverado	Body	HVAC Control Module Auto																																																										
K	2007	Silverado	Body	HVAC Control Module Manual																																																										
K	2007	Silverado	Body	Instrument Panel Cluster																																																										
K	2007	Silverado	Body	Memory Seat Module																					V	V																																				
K	2007	Silverado	Body	Park Assist Module																																																										
K	2007	Silverado	Body	Passenger Door Switch																																																										
K	2007	Silverado	Body	Passenger Presence System																																																										
K	2007	Silverado	Body	Radio																																																										
K	2007	Silverado	Body	Rear Heated Seat Module																																																										
K	2007	Silverado	Body	Rear HVAC/RSA																																																										
K	2007	Silverado	Body	Rollover Sensor																																																										
K	2007	Silverado	Body	Supplemental Inflatable Restraint																			V																																							
K	2007	Silverado	Body	Theft Deterrent Module		V																																																								
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES													V																																												
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																									
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																									
K	2007	Tahoe	Body	Amplifier (Bose)																																																									
K	2007	Tahoe	Body	Assist Step Controller																																																									
K	2007	Tahoe	Body	Body Control Module			V																													V																										
K	2007	Tahoe	Body	Body Control Module (aux.)																																																									
K	2007	Tahoe	Body	Digital Radio Receiver																																																									
K	2007	Tahoe	Body	Driver Door Switch																																																									
K	2007	Tahoe	Body	HVAC Control Module Auto																																																									
K	2007	Tahoe	Body	HVAC Control Module Manual																																																									
K	2007	Tahoe	Body	Instrument Panel Cluster																																																									
K	2007	Tahoe	Body	Lift Gate Module																																																									
K	2007	Tahoe	Body	Memory Seat Module																					V	V																																				
K	2007	Tahoe	Body	Park Assist Module																																																									
K	2007	Tahoe	Body	Passenger Door Switch																																																									
K	2007	Tahoe	Body	Passenger Presence System																																																									
K	2007	Tahoe	Body	Radio																																																									
K	2007	Tahoe	Body	Rear Heated Seat Module																																																									
K	2007	Tahoe	Body	Rear HVAC/RSA																																																									
K	2007	Tahoe	Body	Rollover Sensor																																																									
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																			V																																						
K	2007	Tahoe	Body	Theft Deterrent Module		V																																																								
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																				
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																				
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																				
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																				
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2008	Avalanche	Chassis	Electronic Brake Control Module													V																																												
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																									
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																									
K	2008	Avalanche	Body	Amplifier (Bose)																																																									
K	2008	Avalanche	Body	Assist Step Controller																																																									
K	2008	Avalanche	Body	Body Control Module			V																													V																										
K	2008	Avalanche	Body	Body Control Module (aux.)																																																									
K	2008	Avalanche	Body	Digital Radio Receiver																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2008	Avalanche	Body	Driver Door Switch																																																										
K	2008	Avalanche	Body	HVAC Control Module Auto																																																										
K	2008	Avalanche	Body	HVAC Control Module Manual																																																										
K	2008	Avalanche	Body	Instrument Panel Cluster																																																										
K	2008	Avalanche	Body	Memory Seat Module																					V	V																																					
K	2008	Avalanche	Body	Park Assist Module																																																										
K	2008	Avalanche	Body	Passenger Door Switch																																																										
K	2008	Avalanche	Body	Passenger Presence System																																																										
K	2008	Avalanche	Body	Radio																																																										
K	2008	Avalanche	Body	Rear Heated Seat Module																																																										
K	2008	Avalanche	Body	Rear HVAC/RSA																																																										
K	2008	Avalanche	Body	Rollover Sensor																																																										
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																			V																																							
K	2008	Avalanche	Body	Theft Deterrent Module		V																																																									
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																					
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Suburban	Chassis	EBCM Under 8600 GVW													V																																													
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																													
K	2008	Suburban	Chassis	Electronic Suspension Control																																																										
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																										
K	2008	Suburban	Body	Amplifier (Bose)																																																										
K	2008	Suburban	Body	Assist Step Controller																																																										
K	2008	Suburban	Body	Body Control Module			V																													V																											
K	2008	Suburban	Body	Body Control Module (aux.)																																																										
K	2008	Suburban	Body	Digital Radio Receiver																																																										
K	2008	Suburban	Body	Driver Door Switch																																																										
K	2008	Suburban	Body	HVAC Control Module Auto																																																										
K	2008	Suburban	Body	HVAC Control Module Manual																																																										
K	2008	Suburban	Body	Instrument Panel Cluster																																																										
K	2008	Suburban	Body	Lift Gate Module																																																										
K	2008	Suburban	Body	Memory Seat Module																					V	V																																					
K	2008	Suburban	Body	Park Assist Module																																																										
K	2008	Suburban	Body	Passenger Door Switch																																																										
K	2008	Suburban	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2008	Suburban	Body	Radio																																																											
K	2008	Suburban	Body	Rear Heated Seat Module																																																												
K	2008	Suburban	Body	Rear HVAC/RSA																																																												
K	2008	Suburban	Body	Rollover Sensor																																																												
K	2008	Suburban	Body	Supplemental Inflatable Restraint																			V																																									
K	2008	Suburban	Body	Theft Deterrent Module		V																																																										
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																							
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																							
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																							
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																							
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																							
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																							
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																							
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																							
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																			V				
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																															
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																															
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW													V																																															
K	2008	Silverado	Chassis	Electronic Suspension Control																																																												
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																												
K	2008	Silverado	Body	Amplifier (Bose)																																																												
K	2008	Silverado	Body	Body Control Module			V																													V																											
K	2008	Silverado	Body	Body Control Module (aux.)																																																												
K	2008	Silverado	Body	Digital Radio Receiver																																																												
K	2008	Silverado	Body	Driver Door Switch																																																												
K	2008	Silverado	Body	HVAC Control Module Auto																																																												
K	2008	Silverado	Body	HVAC Control Module Manual																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2008	Silverado	Body	Instrument Panel Cluster																																																										
K	2008	Silverado	Body	Memory Seat Module																					V	V																																				
K	2008	Silverado	Body	Park Assist Module																																																										
K	2008	Silverado	Body	Passenger Door Switch																																																										
K	2008	Silverado	Body	Passenger Presence System																																																										
K	2008	Silverado	Body	Radio																																																										
K	2008	Silverado	Body	Rear Heated Seat Module																																																										
K	2008	Silverado	Body	Rear HVAC/RSA																																																										
K	2008	Silverado	Body	Rollover Sensor																																																										
K	2008	Silverado	Body	Supplemental Inflatable Restraint																			V																																							
K	2008	Silverado	Body	Theft Deterrent Module		V																																																								
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Tahoe	Chassis	Electronic Brake Control Module													V																																													
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2008	Tahoe	Body	Amplifier (Bose)																																																										
K	2008	Tahoe	Body	Assist Step Controller																																																										
K	2008	Tahoe	Body	Body Control Module			V																													V																										
K	2008	Tahoe	Body	Body Control Module (aux.)																																																										
K	2008	Tahoe	Body	Digital Radio Receiver																																																										
K	2008	Tahoe	Body	Driver Door Switch																																																										
K	2008	Tahoe	Body	HVAC Control Module Auto																																																										
K	2008	Tahoe	Body	HVAC Control Module Manual																																																										
K	2008	Tahoe	Body	Instrument Panel Cluster																																																										
K	2008	Tahoe	Body	Lift Gate Module																																																										
K	2008	Tahoe	Body	Memory Seat Module																					V	V																																				
K	2008	Tahoe	Body	Park Assist Module																																																										
K	2008	Tahoe	Body	Passenger Door Switch																																																										
K	2008	Tahoe	Body	Passenger Presence System																																																										
K	2008	Tahoe	Body	Radio																																																										
K	2008	Tahoe	Body	Rear Heated Seat Module																																																										
K	2008	Tahoe	Body	Rear HVAC/RSA																																																										
K	2008	Tahoe	Body	Rollover Sensor																																																										
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																			V																																							
K	2008	Tahoe	Body	Theft Deterrent Module		V																																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																V					
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																									
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																									
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																									
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
K	2008	Tahoe Hybrid	Body	Body Control Module			V																													V																									
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																																									
K	2008	Tahoe Hybrid	Body	HVAC Control Module																																																									
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																									
K	2008	Tahoe Hybrid	Body	Memory Seat Module																					V	V																																			
K	2008	Tahoe Hybrid	Body	Park Assist Module																																																									
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																									
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																																									
K	2008	Tahoe Hybrid	Body	Radio																																																									
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																									
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																									
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																			V																																						
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module		V																																																							
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																				
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																									
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																									
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																				
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																									
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																									
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																				
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																									
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																									
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																				
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2009	Avalanche	Chassis	Electronic Brake Control Module													V																																												
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																									
K	2009	Avalanche	Body	Amplifier (Bose)																																																									
K	2009	Avalanche	Body	Assist Step Controller																																																									
K	2009	Avalanche	Body	Body Control Module			V																													V																										
K	2009	Avalanche	Body	Body Control Module (aux.)																																																									
K	2009	Avalanche	Body	Digital Radio Receiver																																																									
K	2009	Avalanche	Body	Driver Door Switch																																																									
K	2009	Avalanche	Body	HVAC Control Module Auto																																																									
K	2009	Avalanche	Body	HVAC Control Module Manual																																																									
K	2009	Avalanche	Body	Instrument Panel Cluster																																																									
K	2009	Avalanche	Body	Memory Seat Module																					V	V																																				
K	2009	Avalanche	Body	Park Assist Module																																																									
K	2009	Avalanche	Body	Passenger Door Switch																																																									
K	2009	Avalanche	Body	Passenger Presence System																																																									
K	2009	Avalanche	Body	Radio																																																									
K	2009	Avalanche	Body	Rear Heated Seat Module																																																									
K	2009	Avalanche	Body	Rear HVAC/RSA																																																									
K	2009	Avalanche	Body	Rollover Sensor																																																									
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																			V																																						
K	2009	Avalanche	Body	Theft Deterrent Module		V																																																								
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																				
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																				
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES													V																																												
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																												
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES													V																																												
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																									
K	2009	Cheyenne	Body	Amplifier (Bose)																																																									
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																									
K	2009	Cheyenne	Body	Digital Radio Receiver																																																									
K	2009	Cheyenne	Body	Driver Door Switch																																																									
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																									
K	2009	Cheyenne	Body	Park Assist Module																																																									
K	2009	Cheyenne	Body	Passenger Door Switch																																																									
K	2009	Cheyenne	Body	Passenger Presence System																																																									
K	2009	Cheyenne	Body	Rear Heated Seat Module																																																									
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																									
K	2009	Cheyenne	Body	Rollover Sensor																																																									
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																			V																																						
K	2009	Cheyenne	Body	Theft Deterrent Module		V																																																								
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																				
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																				
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																					
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																					
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Suburban	Chassis	EBCM Under 8600 GVW													V																																													
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																													
K	2009	Suburban	Chassis	Electronic Suspension Control																																																										
K	2009	Suburban	Chassis	Trailer Brake Control Module																																																										
K	2009	Suburban	Body	Amplifier (Bose)																																																										
K	2009	Suburban	Body	Assist Step Controller																																																										
K	2009	Suburban	Body	Body Control Module			V																													V																											
K	2009	Suburban	Body	Body Control Module (aux.)																																																										
K	2009	Suburban	Body	Digital Radio Receiver																																																										
K	2009	Suburban	Body	Driver Door Switch																																																										
K	2009	Suburban	Body	HVAC Control Module Auto																																																										
K	2009	Suburban	Body	HVAC Control Module Manual																																																										
K	2009	Suburban	Body	Instrument Panel Cluster																																																										
K	2009	Suburban	Body	Left Side Object Detection Module																																																										
K	2009	Suburban	Body	Lift Gate Module																																																										
K	2009	Suburban	Body	Memory Seat Module																					V	V																																				
K	2009	Suburban	Body	Park Assist Module																																																										
K	2009	Suburban	Body	Passenger Door Switch																																																										
K	2009	Suburban	Body	Passenger Presence System																																																										
K	2009	Suburban	Body	Radio																																																										
K	2009	Suburban	Body	Rear Heated Seat Module																																																										
K	2009	Suburban	Body	Rear HVAC/RSA																																																										
K	2009	Suburban	Body	Right Side Object Detection Module																																																										
K	2009	Suburban	Body	Rollover Sensor																																																										
K	2009	Suburban	Body	Supplemental Inflatable Restraint																			V																																							
K	2009	Suburban	Body	Theft Deterrent Module		V																																																								
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																		V		
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																					
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																					
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic			V		V																																																				
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual			V		V																																																	V			
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																					
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																V				
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																													
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																													
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES													V																																													
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																													
K	2009	Silverado	Chassis	Electronic Suspension Control																																																										
K	2009	Silverado	Chassis	Trailer Brake Control Module																																																										
K	2009	Silverado	Body	Amplifier (Bose)																																																										
K	2009	Silverado	Body	Body Control Module			V																													V																											
K	2009	Silverado	Body	Body Control Module (aux.)																																																										
K	2009	Silverado	Body	Digital Radio Receiver																																																										
K	2009	Silverado	Body	Driver Door Switch																																																										
K	2009	Silverado	Body	HVAC Control Module Auto																																																										
K	2009	Silverado	Body	HVAC Control Module Manual																																																										
K	2009	Silverado	Body	Instrument Panel Cluster																																																										
K	2009	Silverado	Body	Memory Seat Module																					V	V																																				
K	2009	Silverado	Body	Park Assist Module																																																										
K	2009	Silverado	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2009	Silverado	Body	Passenger Presence System																																																										
K	2009	Silverado	Body	Radio																																																										
K	2009	Silverado	Body	Rear Heated Seat Module																																																										
K	2009	Silverado	Body	Rear HVAC/RSA																																																										
K	2009	Silverado	Body	Rollover Sensor																																																										
K	2009	Silverado	Body	Supplemental Inflatable Restraint																			V																																							
K	2009	Silverado	Body	Theft Deterrent Module		V																																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																V					
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Silverado Hybrid	Body	Body Control Module			V																													V																										
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2009	Silverado Hybrid	Body	HVAC Control Module																																																										
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Silverado Hybrid	Body	Memory Seat Module																					V	V																																				
K	2009	Silverado Hybrid	Body	Park Assist Module																																																										
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2009	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2009	Silverado Hybrid	Body	Radio																																																										
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																										
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																			V																																							
K	2009	Silverado Hybrid	Body	Theft Deterrent Module		V																																																								
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																					
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Tahoe	Chassis	Electronic Brake Control Module													V																																													
K	2009	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2009	Tahoe	Body	Amplifier (Bose)																																																										
K	2009	Tahoe	Body	Assist Step Controller																																																										
K	2009	Tahoe	Body	Body Control Module			V																													V																										
K	2009	Tahoe	Body	Body Control Module (aux.)																																																										
K	2009	Tahoe	Body	Digital Radio Receiver																																																										
K	2009	Tahoe	Body	Driver Door Switch																																																										
K	2009	Tahoe	Body	HVAC Control Module Auto																																																										
K	2009	Tahoe	Body	HVAC Control Module Manual																																																										
K	2009	Tahoe	Body	Instrument Panel Cluster																																																										
K	2009	Tahoe	Body	Left Side Object Detection Module																																																										
K	2009	Tahoe	Body	Lift Gate Module																																																										
K	2009	Tahoe	Body	Memory Seat Module																					V	V																																				
K	2009	Tahoe	Body	Park Assist Module																																																										
K	2009	Tahoe	Body	Passenger Door Switch																																																										
K	2009	Tahoe	Body	Passenger Presence System																																																										
K	2009	Tahoe	Body	Radio																																																										
K	2009	Tahoe	Body	Rear Heated Seat Module																																																										
K	2009	Tahoe	Body	Rear HVAC/RSA																																																										
K	2009	Tahoe	Body	Right Side Object Detection Module																																																										
K	2009	Tahoe	Body	Rollover Sensor																																																										
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																			V																																							
K	2009	Tahoe	Body	Theft Deterrent Module		V																																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V						
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Tahoe Hybrid	Body	Body Control Module			V																													V																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																																									
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																																									
K	2009	Tahoe Hybrid	Body	HVAC Control Module																																																									
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																									
K	2009	Tahoe Hybrid	Body	Park Assist Module																																																									
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																									
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																																									
K	2009	Tahoe Hybrid	Body	Radio																																																									
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																									
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																									
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																									
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																			V																																						
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module		V																																																							
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V				
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																									
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																									
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																V				
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																									
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																									
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
K	2010	Avalanche	Chassis	Electronic Brake Control Module													V																																												
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																									
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Avalanche	Body	Amplifier (Bose)																																																									
K	2010	Avalanche	Body	Assist Step Controller																																																									
K	2010	Avalanche	Body	Body Control Module			V																													V																									
K	2010	Avalanche	Body	Body Control Module (aux.)																																																									
K	2010	Avalanche	Body	Digital Radio Receiver																																																									
K	2010	Avalanche	Body	Driver Door Switch																																																									
K	2010	Avalanche	Body	HVAC Control Module Auto																																																									
K	2010	Avalanche	Body	HVAC Control Module Manual																																																									
K	2010	Avalanche	Body	Instrument Panel Cluster																																																									
K	2010	Avalanche	Body	Memory Seat Module																					V	V																																			
K	2010	Avalanche	Body	Park Assist Module																																																									
K	2010	Avalanche	Body	Passenger Door Switch																																																									
K	2010	Avalanche	Body	Passenger Presence System																																																									
K	2010	Avalanche	Body	Radio																																																									
K	2010	Avalanche	Body	Rear Heated Seat Module																																																									
K	2010	Avalanche	Body	Rear HVAC/RSA																																																									
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																									
K	2010	Avalanche	Body	Theft Deterrent Module		V																																																							
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																V				
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V					
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES													V																																													
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES													V																																													
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																													
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES													V																																													
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Cheyenne	Body	Amplifier (Bose)																																																										
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2010	Cheyenne	Body	Digital Radio Receiver																																																										
K	2010	Cheyenne	Body	Driver Door Switch																																																										
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2010	Cheyenne	Body	Park Assist Module																																																										
K	2010	Cheyenne	Body	Passenger Door Switch																																																										
K	2010	Cheyenne	Body	Passenger Presence System																																																										
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2010	Cheyenne	Body	Theft Deterrent Module		V																																																								
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																					
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																					
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																V					
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																V					
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Suburban	Chassis	EBCM Under 8600 GVW													V																																													
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																													
K	2010	Suburban	Chassis	Electronic Suspension Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Body	Amplifier (Bose)																																																										
K	2010	Suburban	Body	Assist Step Controller																																																										
K	2010	Suburban	Body	Body Control Module			V																													V																										
K	2010	Suburban	Body	Body Control Module (aux.)																																																										
K	2010	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2010	Suburban	Body	Driver Door Switch																																																								
K	2010	Suburban	Body	HVAC Control Module Auto																																																								
K	2010	Suburban	Body	HVAC Control Module Manual																																																								
K	2010	Suburban	Body	Instrument Panel Cluster																																																								
K	2010	Suburban	Body	Left Side Object Detection Module																																																								
K	2010	Suburban	Body	Lift Gate Module																																																								
K	2010	Suburban	Body	Memory Seat Module																					V	V																																		
K	2010	Suburban	Body	Park Assist Module																																																								
K	2010	Suburban	Body	Passenger Door Switch																																																								
K	2010	Suburban	Body	Passenger Presence System																																																								
K	2010	Suburban	Body	Radio																																																								
K	2010	Suburban	Body	Rear Heated Seat Module																																																								
K	2010	Suburban	Body	Rear HVAC/RSA																																																								
K	2010	Suburban	Body	Right Side Object Detection Module																																																								
K	2010	Suburban	Body	Supplemental Inflatable Restraint																																																								
K	2010	Suburban	Body	Theft Deterrent Module		V																																																						
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic					V																																															V			V
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual					V																																																V			
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V				
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V				
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																															V				
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V				
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic					V																																															V				V
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual					V																																																	V		
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																															V				
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																															V				
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																											
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																											
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES													V																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																											
K	2010	Silverado	Chassis	Electronic Suspension Control																																																								
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
K	2010	Silverado	Body	Amplifier (Bose)																																																								
K	2010	Silverado	Body	Body Control Module			V																													V																									
K	2010	Silverado	Body	Body Control Module (aux.)																																																								
K	2010	Silverado	Body	Digital Radio Receiver																																																								
K	2010	Silverado	Body	Driver Door Switch																																																								
K	2010	Silverado	Body	HVAC Control Module Auto																																																								
K	2010	Silverado	Body	HVAC Control Module Manual																																																								
K	2010	Silverado	Body	Instrument Panel Cluster																																																								
K	2010	Silverado	Body	Memory Seat Module																					V	V																																			
K	2010	Silverado	Body	Park Assist Module																																																								
K	2010	Silverado	Body	Passenger Door Switch																																																								
K	2010	Silverado	Body	Passenger Presence System																																																								
K	2010	Silverado	Body	Radio																																																								
K	2010	Silverado	Body	Rear Heated Seat Module																																																								
K	2010	Silverado	Body	Rear HVAC/RSA																																																								
K	2010	Silverado	Body	Supplemental Inflatable Restraint																																																								
K	2010	Silverado	Body	Theft Deterrent Module		V																																																						
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V				
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																								
K	2010	Silverado Hybrid	Body	Body Control Module			V																													V																									
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																								
K	2010	Silverado Hybrid	Body	Driver Door Switch																																																								
K	2010	Silverado Hybrid	Body	Heated Seat Module																																																								
K	2010	Silverado Hybrid	Body	HVAC Control Module																																																								
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
K	2010	Silverado Hybrid	Body	Park Assist Module																																																								
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																																								
K	2010	Silverado Hybrid	Body	Passenger Presence System																																																								
K	2010	Silverado Hybrid	Body	Radio																																																								
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2010	Silverado Hybrid	Body	Theft Deterrent Module		V																																																							
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V			
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																															V			
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2010	Tahoe	Chassis	Electronic Brake Control Module													V																																											
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																									
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Tahoe	Body	Amplifier (Bose)																																																									
K	2010	Tahoe	Body	Assist Step Controller																																																									
K	2010	Tahoe	Body	Body Control Module			V																													V																										
K	2010	Tahoe	Body	Body Control Module (aux.)																																																									
K	2010	Tahoe	Body	Digital Radio Receiver																																																									
K	2010	Tahoe	Body	Driver Door Switch																																																									
K	2010	Tahoe	Body	HVAC Control Module Auto																																																									
K	2010	Tahoe	Body	HVAC Control Module Manual																																																									
K	2010	Tahoe	Body	Instrument Panel Cluster																																																									
K	2010	Tahoe	Body	Left Side Object Detection Module																																																									
K	2010	Tahoe	Body	Lift Gate Module																																																									
K	2010	Tahoe	Body	Memory Seat Module																					V	V																																				
K	2010	Tahoe	Body	Park Assist Module																																																									
K	2010	Tahoe	Body	Passenger Door Switch																																																									
K	2010	Tahoe	Body	Passenger Presence System																																																									
K	2010	Tahoe	Body	Radio																																																									
K	2010	Tahoe	Body	Rear Heated Seat Module																																																									
K	2010	Tahoe	Body	Rear HVAC/RSA																																																									
K	2010	Tahoe	Body	Right Side Object Detection Module																																																									
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																									
K	2010	Tahoe	Body	Theft Deterrent Module		V																																																							
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V			
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
K	2010	Tahoe Hybrid	Body	Body Control Module			V																													V																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2010	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2010	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2010	Tahoe Hybrid	Body	Radio																																																										
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module		V																																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																V					
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module					V																																																V					
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module					V																																																V					
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2011	Avalanche	Chassis	Electronic Brake Control Module													V																																													
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Avalanche	Body	Amplifier (Bose)																																																										
K	2011	Avalanche	Body	Assist Step Controller																																																										
K	2011	Avalanche	Body	Body Control Module			V																													V																										
K	2011	Avalanche	Body	Body Control Module (aux.)																																																										
K	2011	Avalanche	Body	Digital Radio Receiver																																																										
K	2011	Avalanche	Body	Driver Door Switch																																																										
K	2011	Avalanche	Body	HVAC Control Module Auto																																																										
K	2011	Avalanche	Body	HVAC Control Module Manual																																																										
K	2011	Avalanche	Body	Instrument Panel Cluster																																																										
K	2011	Avalanche	Body	Memory Seat Module																					V	V																																				
K	2011	Avalanche	Body	Park Assist Module																																																										
K	2011	Avalanche	Body	Passenger Door Switch																																																										
K	2011	Avalanche	Body	Passenger Presence System																																																										
K	2011	Avalanche	Body	Radio																																																										
K	2011	Avalanche	Body	Rear Heated Seat Module																																																										
K	2011	Avalanche	Body	Rear HVAC/RSA																																																										
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2011	Avalanche	Body	Theft Deterrent Module		V																																																								
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																		V			
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES													V																																													
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES													V																																													
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																													
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES													V																																													
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Cheyenne	Body	Amplifier (Bose)																																																										
K	2011	Cheyenne	Body	Body Control Module			V																													V																											
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2011	Cheyenne	Body	Digital Radio Receiver																																																										
K	2011	Cheyenne	Body	Driver Door Switch																																																										
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2011	Cheyenne	Body	Park Assist Module																																																										
K	2011	Cheyenne	Body	Passenger Door Switch																																																										
K	2011	Cheyenne	Body	Passenger Presence System																																																										
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2011	Cheyenne	Body	Theft Deterrent Module		V																																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																					
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																					
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																		V			
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2011	Suburban	Chassis	EBCM Under 8600 GVW													V																																													
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																													
K	2011	Suburban	Chassis	Electronic Suspension Control																																																										
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Suburban	Body	Amplifier (Bose)																																																										
K	2011	Suburban	Body	Assist Step Controller																																																										
K	2011	Suburban	Body	Body Control Module			V																													V																											
K	2011	Suburban	Body	Body Control Module (aux.)																																																										
K	2011	Suburban	Body	Digital Radio Receiver																																																										
K	2011	Suburban	Body	Driver Door Switch																																																										
K	2011	Suburban	Body	HVAC Control Module Auto																																																										
K	2011	Suburban	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2011	Suburban	Body	Instrument Panel Cluster																																																										
K	2011	Suburban	Body	Left Side Object Detection Module																																																										
K	2011	Suburban	Body	Lift Gate Module																																																										
K	2011	Suburban	Body	Memory Seat Module																					V	V																																					
K	2011	Suburban	Body	Park Assist Module																																																										
K	2011	Suburban	Body	Passenger Door Switch																																																										
K	2011	Suburban	Body	Passenger Presence System																																																										
K	2011	Suburban	Body	Radio																																																										
K	2011	Suburban	Body	Rear Heated Seat Module																																																										
K	2011	Suburban	Body	Rear HVAC/RSA																																																										
K	2011	Suburban	Body	Right Side Object Detection Module																																																										
K	2011	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2011	Suburban	Body	Theft Deterrent Module		V																																																								
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic					V																																															V		V
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual					V																																																V		
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																									
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V					
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module					V																																															V					
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module			V		V																																																					
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																															V					
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic					V																																															V					V
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual					V																																															V	V				
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																															V					
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module					V																																															V					
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																															V					
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																										
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																												
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES													V																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																											
K	2011	Silverado	Chassis	Electronic Suspension Control																																																								
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
K	2011	Silverado	Body	Amplifier (Bose)																																																								
K	2011	Silverado	Body	Body Control Module			V																													V																									
K	2011	Silverado	Body	Body Control Module (aux.)																																																								
K	2011	Silverado	Body	Digital Radio Receiver																																																								
K	2011	Silverado	Body	Driver Door Switch																																																								
K	2011	Silverado	Body	HVAC Control Module Auto																																																								
K	2011	Silverado	Body	HVAC Control Module Manual																																																								
K	2011	Silverado	Body	Instrument Panel Cluster																																																								
K	2011	Silverado	Body	Memory Seat Module																					V	V																																			
K	2011	Silverado	Body	Park Assist Module																																																								
K	2011	Silverado	Body	Passenger Door Switch																																																								
K	2011	Silverado	Body	Passenger Presence System																																																								
K	2011	Silverado	Body	Radio																																																								
K	2011	Silverado	Body	Rear Heated Seat Module																																																								
K	2011	Silverado	Body	Rear HVAC/RSA																																																								
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																																								
K	2011	Silverado	Body	Theft Deterrent Module		V																																																						
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V			
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																								
K	2011	Silverado Hybrid	Body	Body Control Module			V																													V																									
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																								
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																								
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																								
K	2011	Silverado Hybrid	Body	HVAC Control Module																																																								
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
K	2011	Silverado Hybrid	Body	Park Assist Module																																																								
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																								
K	2011	Silverado Hybrid	Body	Passenger Presence System																																																								
K	2011	Silverado Hybrid	Body	Radio																																																								
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2011	Silverado Hybrid	Body	Theft Deterrent Module		V																																																								
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																	V			
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																									
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																									
K	2011	Tahoe	Chassis	Electronic Brake Control Module													V																																												
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Tahoe	Body	Amplifier (Bose)																																																										
K	2011	Tahoe	Body	Assist Step Controller																																																										
K	2011	Tahoe	Body	Body Control Module			V																													V																											
K	2011	Tahoe	Body	Body Control Module (aux.)																																																										
K	2011	Tahoe	Body	Digital Radio Receiver																																																										
K	2011	Tahoe	Body	Driver Door Switch																																																										
K	2011	Tahoe	Body	HVAC Control Module Auto																																																										
K	2011	Tahoe	Body	HVAC Control Module Manual																																																										
K	2011	Tahoe	Body	Instrument Panel Cluster																																																										
K	2011	Tahoe	Body	Left Side Object Detection Module																																																										
K	2011	Tahoe	Body	Lift Gate Module																																																										
K	2011	Tahoe	Body	Memory Seat Module																					V	V																																				
K	2011	Tahoe	Body	Park Assist Module																																																										
K	2011	Tahoe	Body	Passenger Door Switch																																																										
K	2011	Tahoe	Body	Passenger Presence System																																																										
K	2011	Tahoe	Body	Radio																																																										
K	2011	Tahoe	Body	Rear Heated Seat Module																																																										
K	2011	Tahoe	Body	Rear HVAC/RSA																																																										
K	2011	Tahoe	Body	Right Side Object Detection Module																																																										
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2011	Tahoe	Body	Theft Deterrent Module		V																																																								
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																	V			
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2011	Tahoe Hybrid	Body	Body Control Module			V																													V																											
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2011	Tahoe Hybrid	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2011	Tahoe Hybrid	Body	Radio																																																										
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module		V																																																								
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																															V				
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																														V				
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2012	Avalanche	Chassis	Electronic Brake Control Module													V																																													
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Avalanche	Body	Amplifier (Bose)																																																										
K	2012	Avalanche	Body	Assist Step Controller																																																										
K	2012	Avalanche	Body	Body Control Module			V																													V			V																							
K	2012	Avalanche	Body	Body Control Module (aux.)																																																										
K	2012	Avalanche	Body	Digital Radio Receiver																																																										
K	2012	Avalanche	Body	Driver Door Switch																																																										
K	2012	Avalanche	Body	HVAC Control Module Auto																																																										
K	2012	Avalanche	Body	HVAC Control Module Manual																																																										
K	2012	Avalanche	Body	Instrument Panel Cluster																																																										
K	2012	Avalanche	Body	Memory Seat Module																					V	V																																				
K	2012	Avalanche	Body	Navigation Radio																																																										
K	2012	Avalanche	Body	Park Assist Module																																																										
K	2012	Avalanche	Body	Passenger Door Switch																																																										
K	2012	Avalanche	Body	Passenger Presence System																																																										
K	2012	Avalanche	Body	Radio																																																										
K	2012	Avalanche	Body	Rear Heated Seat Module																																																										
K	2012	Avalanche	Body	Rear HVAC/RSA																																																										
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2012	Avalanche	Body	Theft Deterrent Module		V																																																								
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic					V																																														V				V
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual					V																																															V				
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																														V				
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																																V			
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES													V																																											
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES													V																																											
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																											
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES													V																																											
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																									
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Cheyenne	Body	Amplifier (Bose)																																																									
K	2012	Cheyenne	Body	Body Control Module			V																													V			V																						
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																									
K	2012	Cheyenne	Body	Digital Radio Receiver																																																									
K	2012	Cheyenne	Body	Driver Door Switch																																																									
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																									
K	2012	Cheyenne	Body	Park Assist Module																																																									
K	2012	Cheyenne	Body	Passenger Door Switch																																																									
K	2012	Cheyenne	Body	Passenger Presence System																																																									
K	2012	Cheyenne	Body	Rear Heated Seat Module																																																									
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																									
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																									
K	2012	Cheyenne	Body	Theft Deterrent Module		V																																																							
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																				
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																									
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																									
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																																V			
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																									
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																									
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																V			
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																									
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
K	2012	Suburban	Chassis	EBCM Under 8600 GVW													V																																											
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																											
K	2012	Suburban	Chassis	Electronic Suspension Control																																																									
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Suburban	Body	Amplifier (Bose)																																																									
K	2012	Suburban	Body	Assist Step Controller																																																									
K	2012	Suburban	Body	Body Control Module			V																													V			V																						
K	2012	Suburban	Body	Body Control Module (aux.)																																																									
K	2012	Suburban	Body	Digital Radio Receiver																																																									
K	2012	Suburban	Body	Driver Door Switch																																																									
K	2012	Suburban	Body	HVAC Control Module Auto																																																									
K	2012	Suburban	Body	HVAC Control Module Manual																																																									
K	2012	Suburban	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2012	Suburban	Body	Left Side Object Detection Module																																																									
K	2012	Suburban	Body	Lift Gate Module																																																									
K	2012	Suburban	Body	Memory Seat Module																					V	V																																				
K	2012	Suburban	Body	Navigation Radio																																																								
K	2012	Suburban	Body	Park Assist Module																																																								
K	2012	Suburban	Body	Passenger Door Switch																																																								
K	2012	Suburban	Body	Passenger Presence System																																																								
K	2012	Suburban	Body	Radio																																																								
K	2012	Suburban	Body	Rear Heated Seat Module																																																								
K	2012	Suburban	Body	Rear HVAC/RSA																																																								
K	2012	Suburban	Body	Right Side Object Detection Module																																																								
K	2012	Suburban	Body	Supplemental Inflatable Restraint																																																								
K	2012	Suburban	Body	Theft Deterrent Module		V																																																							
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic					V																																															V			V
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual					V																																																V		
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V			
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V			
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																															V			
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic					V																																															V			V
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual					V																																															V	V		
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																															V			
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module					V																																															V			
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																															V			
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																											
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																											
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES													V																																											
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2012	Silverado	Chassis	Electronic Suspension Control																																																								
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
K	2012	Silverado	Body	Amplifier (Bose)																																																								
K	2012	Silverado	Body	Body Control Module			V																												V			V																						
K	2012	Silverado	Body	Body Control Module (aux.)																																																								
K	2012	Silverado	Body	Digital Radio Receiver																																																								
K	2012	Silverado	Body	Driver Door Switch																																																								
K	2012	Silverado	Body	HVAC Control Module Auto																																																								
K	2012	Silverado	Body	HVAC Control Module Manual																																																								
K	2012	Silverado	Body	Instrument Panel Cluster																																																								
K	2012	Silverado	Body	Memory Seat Module																					V	V																																			
K	2012	Silverado	Body	Navigation Radio																																																								
K	2012	Silverado	Body	Park Assist Module																																																								
K	2012	Silverado	Body	Passenger Door Switch																																																								
K	2012	Silverado	Body	Passenger Presence System																																																								
K	2012	Silverado	Body	Radio																																																								
K	2012	Silverado	Body	Rear Heated Seat Module																																																								
K	2012	Silverado	Body	Rear HVAC/RSA																																																								
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																																								
K	2012	Silverado	Body	Theft Deterrent Module		V																																																						
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V			
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																								
K	2012	Silverado Hybrid	Body	Body Control Module			V																												V			V																						
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																								
K	2012	Silverado Hybrid	Body	Driver Door Switch																																																								
K	2012	Silverado Hybrid	Body	Heated Seat Module																																																								
K	2012	Silverado Hybrid	Body	HVAC Control Module																																																								
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
K	2012	Silverado Hybrid	Body	Navigation Radio																																																								
K	2012	Silverado Hybrid	Body	Park Assist Module																																																								
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																																								
K	2012	Silverado Hybrid	Body	Passenger Presence System																																																								
K	2012	Silverado Hybrid	Body	Radio																																																								
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2012	Silverado Hybrid	Body	Theft Deterrent Module		V																																																								
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																	V			
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																									
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																									
K	2012	Tahoe	Chassis	EBCM with Trailer Brake													V																																												
K	2012	Tahoe	Chassis	Electronic Suspension Control																																																									
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Tahoe	Body	Amplifier (Bose)																																																									
K	2012	Tahoe	Body	Assist Step Controller																																																									
K	2012	Tahoe	Body	Body Control Module			V																													V			V																							
K	2012	Tahoe	Body	Body Control Module (aux.)																																																									
K	2012	Tahoe	Body	Digital Radio Receiver																																																									
K	2012	Tahoe	Body	Driver Door Switch																																																									
K	2012	Tahoe	Body	HVAC Control Module Auto																																																									
K	2012	Tahoe	Body	HVAC Control Module Manual																																																									
K	2012	Tahoe	Body	Instrument Panel Cluster																																																									
K	2012	Tahoe	Body	Left Side Object Detection Module																																																									
K	2012	Tahoe	Body	Lift Gate Module																																																									
K	2012	Tahoe	Body	Memory Seat Module																					V	V																																				
K	2012	Tahoe	Body	Navigation Radio																																																									
K	2012	Tahoe	Body	Park Assist Module																																																									
K	2012	Tahoe	Body	Passenger Door Switch																																																									
K	2012	Tahoe	Body	Passenger Presence System																																																									
K	2012	Tahoe	Body	Radio																																																									
K	2012	Tahoe	Body	Rear Heated Seat Module																																																									
K	2012	Tahoe	Body	Rear HVAC/RSA																																																									
K	2012	Tahoe	Body	Right Side Object Detection Module																																																									
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																									
K	2012	Tahoe	Body	Theft Deterrent Module		V																																																							
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																	V			
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
K	2012	Tahoe Hybrid	Body	Body Control Module			V																													V			V																							
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																																									
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2012	Tahoe Hybrid	Body	HVAC Control Module																																																								
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																																								
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																								
K	2012	Tahoe Hybrid	Body	Park Assist Module																																																								
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																								
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																																								
K	2012	Tahoe Hybrid	Body	Radio																																																								
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module		V																																																						
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																															V				
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V				
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2013	Avalanche	Chassis	Electronic Brake Control Module													V																																											
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																								
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Avalanche	Body	Amplifier (Bose)																																																								
K	2013	Avalanche	Body	Assist Step Controller																																																								
K	2013	Avalanche	Body	Body Control Module			V																													V			V																					
K	2013	Avalanche	Body	Body Control Module (aux.)																																																								
K	2013	Avalanche	Body	Digital Radio Receiver																																																								
K	2013	Avalanche	Body	Driver Door Switch																																																								
K	2013	Avalanche	Body	HVAC Control Module Auto																																																								
K	2013	Avalanche	Body	HVAC Control Module Manual																																																								
K	2013	Avalanche	Body	Instrument Panel Cluster																																																								
K	2013	Avalanche	Body	Memory Seat Module																					V	V																																		
K	2013	Avalanche	Body	Navigation Radio																																																								
K	2013	Avalanche	Body	Park Assist Module																																																								
K	2013	Avalanche	Body	Passenger Door Switch																																																								
K	2013	Avalanche	Body	Passenger Presence System																																																								
K	2013	Avalanche	Body	Radio																																																								
K	2013	Avalanche	Body	Rear Heated Seat Module																																																								
K	2013	Avalanche	Body	Rear HVAC/RSA																																																								
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																								
K	2013	Avalanche	Body	Theft Deterrent Module		V																																																						
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic					V																																															V			V	
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual					V																																																	V		
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																																V			
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V			
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES													V																																											
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES													V																																											
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																											
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES													V																																											
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																								
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Cheyenne	Body	Amplifier (Bose)																																																								
K	2013	Cheyenne	Body	Body Control Module			V																													V			V																						
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																								
K	2013	Cheyenne	Body	Digital Radio Receiver																																																								
K	2013	Cheyenne	Body	Driver Door Switch																																																								
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																								
K	2013	Cheyenne	Body	Park Assist Module																																																								
K	2013	Cheyenne	Body	Passenger Door Switch																																																								
K	2013	Cheyenne	Body	Passenger Presence System																																																								
K	2013	Cheyenne	Body	Rear Heated Seat Module																																																								
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																								
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																								
K	2013	Cheyenne	Body	Theft Deterrent Module		V																																																						
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																																V			
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																		
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed					V																																																V			
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
K	2013	Suburban	Chassis	EBCM Under 8600 GVW													V																																											
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW													V																																											
K	2013	Suburban	Chassis	Electronic Suspension Control																																																								
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Suburban	Body	Amplifier (Bose)																																																								
K	2013	Suburban	Body	Assist Step Controller																																																								
K	2013	Suburban	Body	Body Control Module			V																													V			V																						
K	2013	Suburban	Body	Body Control Module (aux.)																																																								
K	2013	Suburban	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2013	Suburban	Body	Driver Door Switch																																																										
K	2013	Suburban	Body	HVAC Control Module Auto																																																										
K	2013	Suburban	Body	HVAC Control Module Manual																																																										
K	2013	Suburban	Body	Instrument Panel Cluster																																																										
K	2013	Suburban	Body	Left Side Object Detection Module																																																										
K	2013	Suburban	Body	Lift Gate Module																																																										
K	2013	Suburban	Body	Memory Seat Module																					V	V																																				
K	2013	Suburban	Body	Navigation Radio																																																										
K	2013	Suburban	Body	Park Assist Module																																																										
K	2013	Suburban	Body	Passenger Door Switch																																																										
K	2013	Suburban	Body	Passenger Presence System																																																										
K	2013	Suburban	Body	Radio																																																										
K	2013	Suburban	Body	Rear Heated Seat Module																																																										
K	2013	Suburban	Body	Rear HVAC/RSA																																																										
K	2013	Suburban	Body	Right Side Object Detection Module																																																										
K	2013	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2013	Suburban	Body	Theft Deterrent Module		V																																																								
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic					V																																															V			V			
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual					V																																																	V				
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V						
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																															V						
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V						
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic					V																																															V			V			
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual					V																																															V	V					
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																															V				V		
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																															V						
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module					V																																															V						
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES													V																																													

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES													V																																												
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																												
K	2013	Silverado	Chassis	Electronic Suspension Control																																																										
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2013	Silverado	Body	Amplifier (Bose)																																																										
K	2013	Silverado	Body	Body Control Module			V																													V			V																								
K	2013	Silverado	Body	Body Control Module (aux.)																																																										
K	2013	Silverado	Body	Digital Radio Receiver																																																										
K	2013	Silverado	Body	Driver Door Switch																																																										
K	2013	Silverado	Body	HVAC Control Module Auto																																																										
K	2013	Silverado	Body	HVAC Control Module Manual																																																										
K	2013	Silverado	Body	Instrument Panel Cluster																																																										
K	2013	Silverado	Body	Memory Seat Module																					V	V																																					
K	2013	Silverado	Body	Navigation Radio																																																										
K	2013	Silverado	Body	Park Assist Module																																																										
K	2013	Silverado	Body	Passenger Door Switch																																																										
K	2013	Silverado	Body	Passenger Presence System																																																										
K	2013	Silverado	Body	Radio																																																										
K	2013	Silverado	Body	Rear Heated Seat Module																																																										
K	2013	Silverado	Body	Rear HVAC/RSA																																																										
K	2013	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2013	Silverado	Body	Theft Deterrent Module		V																																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V				
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2013	Silverado Hybrid	Body	Body Control Module			V																													V			V																								
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2013	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2013	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2013	Silverado Hybrid	Body	HVAC Control Module																																																										
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2013	Silverado Hybrid	Body	Navigation Radio																																																										
K	2013	Silverado Hybrid	Body	Park Assist Module																																																										
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2013	Silverado Hybrid	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2013	Silverado Hybrid	Body	Radio																																																									
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																									
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																									
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																									
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2013	Silverado Hybrid	Body	Theft Deterrent Module		V																																																							
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																				
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																									
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																									
K	2013	Tahoe	Chassis	Electronic Brake Control Module													V																																												
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																									
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Tahoe	Body	Amplifier (Bose)																																																									
K	2013	Tahoe	Body	Assist Step Controller																																																									
K	2013	Tahoe	Body	Body Control Module			V																		V											V			V																						
K	2013	Tahoe	Body	Body Control Module (aux.)																																																									
K	2013	Tahoe	Body	Digital Radio Receiver																																																									
K	2013	Tahoe	Body	Driver Door Switch																																																									
K	2013	Tahoe	Body	HVAC Control Module Auto																																																									
K	2013	Tahoe	Body	HVAC Control Module Manual																																																									
K	2013	Tahoe	Body	Instrument Panel Cluster																																																									
K	2013	Tahoe	Body	Left Side Object Detection Module																																																									
K	2013	Tahoe	Body	Lift Gate Module																																																									
K	2013	Tahoe	Body	Memory Seat Module																					V	V																																			
K	2013	Tahoe	Body	Navigation Radio																																																									
K	2013	Tahoe	Body	Park Assist Module																																																									
K	2013	Tahoe	Body	Passenger Door Switch																																																									
K	2013	Tahoe	Body	Passenger Presence System																																																									
K	2013	Tahoe	Body	Radio																																																									
K	2013	Tahoe	Body	Rear Heated Seat Module																																																									
K	2013	Tahoe	Body	Rear HVAC/RSA																																																									
K	2013	Tahoe	Body	Right Side Object Detection Module																																																									
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																									
K	2013	Tahoe	Body	Theft Deterrent Module		V																																																							
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																V				
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
K	2013	Tahoe Hybrid	Body	Body Control Module			V																													V			V																						
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																								
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																								
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																																								
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																																								
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																								
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																								
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																								
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																																								
K	2013	Tahoe Hybrid	Body	Radio																																																								
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module		V																																																						
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																								
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																								
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																								
K	2014	Cheyenne	Chassis	Power Steering Control Module																																																								
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2014	Cheyenne	Body	Body Control Module																																																								
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2014	Cheyenne	Body	Passenger Presence Module																																																								
K	2014	Cheyenne	Body	Instrument Cluster																																																								
K	2014	Cheyenne	Body	Radio Control																																																								
K	2014	Cheyenne	Body	HVAC Control																																																								
K	2014	Cheyenne	Body	Radio																																																								
K	2014	Cheyenne	Body	Amplifier																																																								
K	2014	Cheyenne	Body	Media Disc Player																																																								
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																								
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2014	Cheyenne	Body	HVAC Control Module																																																										
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																										
K	2014	Cheyenne	Body	Parking Assist Control Module																																																										
K	2014	Cheyenne	Body	Frontview Camera Module																																																										
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2014	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2014	Silverado	Chassis	Parking Brake Control Module																																																										
K	2014	Silverado	Chassis	Power Steering Control Module																																																										
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Silverado	Body	Body Control Module																																																										
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Silverado	Body	Passenger Presence Module																																																										
K	2014	Silverado	Body	Instrument Cluster																																																										
K	2014	Silverado	Body	Radio Control																																																										
K	2014	Silverado	Body	HVAC Control																																																										
K	2014	Silverado	Body	Radio																																																										
K	2014	Silverado	Body	Amplifier																																																										
K	2014	Silverado	Body	Media Disc Player																																																										
K	2014	Silverado	Body	Human Machine Interface Control Module																																																										
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2014	Silverado	Body	Parking Assist Control Module																																																										
K	2014	Silverado	Body	Frontview Camera Module																																																										
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																										
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																										
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2014	Silverado HD	Chassis	Suspension Control Module																																																								
K	2014	Silverado HD	Body	Body Control Module																																																								
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2014	Silverado HD	Body	Passenger Presence Module																																																								
K	2014	Silverado HD	Body	Instrument Cluster																																																								
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																								
K	2014	Silverado HD	Body	Base Radio																																																								
K	2014	Silverado HD	Body	Navigation Radio																																																								
K	2014	Silverado HD	Body	Uplevel Radio																																																								
K	2014	Silverado HD	Body	Amplifier																																																								
K	2014	Silverado HD	Body	Rear Audio Control Module																																																								
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																								
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																								
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																								
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																								
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																								
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																								
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																								
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																								
K	2014	Silverado HD	Body	Seat Memory Control Module																																																								
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																								
K	2014	Silverado HD	Body	Parking Assist Control Module																																																								
K	2014	Silverado HD	Body	Theft Deterrent Module		V																																																						
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																								
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																								
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																								
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																								
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																								
K	2014	Suburban	Chassis	Parking Brake Control Module																																																								
K	2014	Suburban	Chassis	Suspension Control Module																																																								
K	2014	Suburban	Body	Body Control Module																																																								
K	2014	Suburban	Body	Auxiliary Body Control Module																																																								
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2014	Suburban	Body	Passenger Presence Module																																																								
K	2014	Suburban	Body	Instrument Cluster																																																								
K	2014	Suburban	Body	Base Radio																																																								
K	2014	Suburban	Body	Navigation Radio																																																								
K	2014	Suburban	Body	Uplevel Radio																																																								
K	2014	Suburban	Body	Amplifier																																																								
K	2014	Suburban	Body	Rear Audio Control Module																																																								
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																								
K	2014	Suburban	Body	Personal Audio Link Control Module																																																								
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																								
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Suburban	Body	Liftgate Control Module																																																										
K	2014	Suburban	Body	Seat Memory Control Module																																																										
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																										
K	2014	Suburban	Body	Assist Step Control Module																																																										
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																										
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																										
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																										
K	2014	Suburban	Body	Parking Assist Control Module																																																										
K	2014	Suburban	Body	Theft Deterrent Module		V																																																								
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																										
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																										
K	2014	Tahoe	Chassis	Suspension Control Module																																																										
K	2014	Tahoe	Body	Body Control Module																																																										
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																										
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Tahoe	Body	Passenger Presence Module																																																										
K	2014	Tahoe	Body	Instrument Cluster																																																										
K	2014	Tahoe	Body	Base Radio																																																										
K	2014	Tahoe	Body	Navigation Radio																																																										
K	2014	Tahoe	Body	Uplevel Radio																																																										
K	2014	Tahoe	Body	Amplifier																																																										
K	2014	Tahoe	Body	Rear Audio Control Module																																																										
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																										
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																										
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Tahoe	Body	Liftgate Control Module																																																										
K	2014	Tahoe	Body	Seat Memory Control Module																																																										
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																										
K	2014	Tahoe	Body	Assist Step Control Module																																																										
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																										
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																										
K	2014	Tahoe	Body	Parking Assist Control Module																																																										
K	2014	Tahoe	Body	Theft Deterrent Module		V																																																								
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																											
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																											
K	2015	Cheyenne	Chassis	Power Steering Control Module																																																											
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Cheyenne	Chassis	Suspension Control Module																																																											
K	2015	Cheyenne	Body	Body Control Module																																																											
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Cheyenne	Body	Passenger Presence Module																																																											
K	2015	Cheyenne	Body	Instrument Cluster																																																											
K	2015	Cheyenne	Body	Radio Controls																																																											
K	2015	Cheyenne	Body	HVAC Controls																																																											
K	2015	Cheyenne	Body	Radio																																																											
K	2015	Cheyenne	Body	Amplifier																																																											
K	2015	Cheyenne	Body	Media Disc Player																																																											
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																											
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																											
K	2015	Cheyenne	Body	HVAC Control Module																																																											
K	2015	Cheyenne	Body	Parking Assist Control Module																																																											
K	2015	Cheyenne	Body	Frontview Camera Module																																																											
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2015	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																										
K	2015	Silverado	Chassis	Power Steering Control Module																																																										
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Silverado	Chassis	Suspension Control Module																																																										
K	2015	Silverado	Body	Body Control Module																																																										
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Silverado	Body	Passenger Presence Module																																																										
K	2015	Silverado	Body	Instrument Cluster																																																										
K	2015	Silverado	Body	Radio Controls																																																										
K	2015	Silverado	Body	HVAC Controls																																																										
K	2015	Silverado	Body	Radio																																																										
K	2015	Silverado	Body	Amplifier																																																										
K	2015	Silverado	Body	Media Disc Player																																																										
K	2015	Silverado	Body	Human Machine Interface Control Module																																																										
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																																										
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2015	Silverado	Body	Parking Assist Control Module																																																										
K	2015	Silverado	Body	Frontview Camera Module																																																										
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2015	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
K	2015	Suburban	Chassis	Parking Brake Control Module																																																										
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2015	Suburban	Chassis	Power Steering Control Module																																																										
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Suburban	Chassis	Suspension Control Module																																																										
K	2015	Suburban	Body	Body Control Module																																																										
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Suburban	Body	Passenger Presence Module																																																										
K	2015	Suburban	Body	Instrument Cluster																																																										
K	2015	Suburban	Body	Radio Controls																																																										
K	2015	Suburban	Body	HVAC Controls																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2015	Suburban	Body	Radio																																																										
K	2015	Suburban	Body	Amplifier																																																										
K	2015	Suburban	Body	Media Disc Player																																																										
K	2015	Suburban	Body	Human Machine Interface Control Module																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2015	Suburban	Body	HVAC Control Module																																																											
K	2015	Suburban	Body	Liftgate Control Module																																																											
K	2015	Suburban	Body	Keyless Entry Control Module																																																											
K	2015	Suburban	Body	Assist Step Control Module																																																											
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																											
K	2015	Suburban	Body	Parking Assist Control Module																																																											
K	2015	Suburban	Body	Frontview Camera Module																																																											
K	2015	Suburban	Body	Steering Column Lock Control Module																																																											
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																											
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																											
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																											
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																											
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																											
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																											
K	2015	Tahoe	Chassis	Power Steering Control Module																																																											
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Tahoe	Chassis	Suspension Control Module																																																											
K	2015	Tahoe	Body	Body Control Module																																																											
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Tahoe	Body	Passenger Presence Module																																																											
K	2015	Tahoe	Body	Instrument Cluster																																																											
K	2015	Tahoe	Body	Radio Controls																																																											
K	2015	Tahoe	Body	HVAC Controls																																																											
K	2015	Tahoe	Body	Radio																																																										
K	2015	Tahoe	Body	Amplifier																																																										
K	2015	Tahoe	Body	Media Disc Player																																																											
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2015	Tahoe	Body	HVAC Control Module																																																											
K	2015	Tahoe	Body	Liftgate Control Module																																																											
K	2015	Tahoe	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2015	Tahoe	Body	Assist Step Control Module																																																										
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2015	Tahoe	Body	Parking Assist Control Module																																																										
K	2015	Tahoe	Body	Frontview Camera Module																																																										
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																										
K	2015	Tahoe	Body	Battery Energy Control Module																																																										
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																										
K	2016	Cheyenne	Chassis	Power Steering Control Module																																																										
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Cheyenne	Chassis	Suspension Control Module																																																										
K	2016	Cheyenne	Body	Body Control Module																																																										
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Cheyenne	Body	Passenger Presence Module																																																										
K	2016	Cheyenne	Body	Instrument Cluster																																																										
K	2016	Cheyenne	Body	Radio Controls																																																										
K	2016	Cheyenne	Body	HVAC Controls																																																										
K	2016	Cheyenne	Body	Radio																																																										
K	2016	Cheyenne	Body	Amplifier																																																										
K	2016	Cheyenne	Body	Media Disc Player																																																										
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																										
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
K	2016	Cheyenne	Body	HVAC Control Module																																																										
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																										
K	2016	Cheyenne	Body	Parking Assist Control Module																																																										
K	2016	Cheyenne	Body	Frontview Camera Module																																																										
K	2016	Cheyenne	Body	Frontview Camera Module																																																										
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2016	Silverado	Chassis	Power Steering Control Module																																																										
K	2016	Silverado	Chassis	Power Steering Control Module																																																										
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Silverado	Chassis	Suspension Control Module																																																										
K	2016	Silverado	Body	Body Control Module																																																										
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Silverado	Body	Passenger Presence Module																																																										
K	2016	Silverado	Body	Instrument Cluster																																																										
K	2016	Silverado	Body	Radio Controls																																																										
K	2016	Silverado	Body	HVAC Controls																																																										
K	2016	Silverado	Body	Radio (IO3)																																																										
K	2016	Silverado	Body	Radio (IOB)																																																										
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
K	2016	Silverado	Body	Amplifier																																																										
K	2016	Silverado	Body	Media Disc Player																																																										
K	2016	Silverado	Body	Human Machine Interface Control Module																																																										
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																										
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																										
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																										
K	2016	Silverado	Body	Parking Assist Control Module																																																										
K	2016	Silverado	Body	Frontview Camera Module																																																										
K	2016	Silverado	Body	Frontview Camera Module																																																										
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
K	2016	Suburban	Chassis	Parking Brake Control Module																																																										
K	2016	Suburban	Chassis	Power Steering Control Module																																																										
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Suburban	Chassis	Suspension Control Module																																																										
K	2016	Suburban	Body	Body Control Module																																																										
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2016	Suburban	Body	Passenger Presence Module																																																										
K	2016	Suburban	Body	Instrument Cluster																																																										
K	2016	Suburban	Body	Radio Controls																																																										
K	2016	Suburban	Body	HVAC Controls																																																										
K	2016	Suburban	Body	Radio																																																										
K	2016	Suburban	Body	Amplifier																																																										
K	2016	Suburban	Body	Media Disc Player																																																										
K	2016	Suburban	Body	Human Machine Interface Control Module																																																											
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																																											
K	2016	Suburban	Body	HVAC Control Module																																																											
K	2016	Suburban	Body	Liftgate Control Module																																																											
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																											
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																											
K	2016	Suburban	Body	Keyless Entry Control Module																																																											
K	2016	Suburban	Body	Assist Step Control Module																																																											
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																											
K	2016	Suburban	Body	Parking Assist Control Module																																																											
K	2016	Suburban	Body	Frontview Camera Module																																																											
K	2016	Suburban	Body	Steering Column Lock Control Module																																																											
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																											
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																											
K	2016	Tahoe	Chassis	Power Steering Control Module																																																											
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2016	Tahoe	Chassis	Suspension Control Module																																																											
K	2016	Tahoe	Body	Body Control Module																																																											
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2016	Tahoe	Body	Passenger Presence Module																																																											
K	2016	Tahoe	Body	Instrument Cluster																																																											
K	2016	Tahoe	Body	Radio Controls																																																											
K	2016	Tahoe	Body	HVAC Controls																																																											
K	2016	Tahoe	Body	Radio																																																											
K	2016	Tahoe	Body	Amplifier																																																											
K	2016	Tahoe	Body	Media Disc Player																																																											
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																											
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																											
K	2016	Tahoe	Body	HVAC Control Module																																																											
K	2016	Tahoe	Body	Liftgate Control Module																																																											
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																											
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																											
K	2016	Tahoe	Body	Keyless Entry Control Module																																																											
K	2016	Tahoe	Body	Assist Step Control Module																																																											
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																											
K	2016	Tahoe	Body	Parking Assist Control Module																																																											
K	2016	Tahoe	Body	Frontview Camera Module																																																											
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																											
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
L	2004	ALL	Chassis	4WAL 3 Sensor																																																												
L	2004	ALL	Body	Body Control Module																												V																																
L	2004	ALL	Body	Instrument Panel Cluster																																																											
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																						
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
L	2005	Astro	Chassis	4WAL 3 Sensor																																																											
L	2005	Astro	Body	Body Control Module																												V																														
L	2005	Astro	Body	Instrument Panel Cluster																																																											
L	2005	Astro	Body	Supplemental Inflatable Restraint																																																											
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module					V																																																						
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																											
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes											V	V	V																																														
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No											V	V	V																																														
L	2005	Equinox	Chassis	Electric Power Steering																																																											
L	2005	Equinox	Body	Body Control Module																													V	V																													
L	2005	Equinox	Body	Instrument Panel Cluster																																																											
L	2005	Equinox	Body	Radio								V																																																			
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																																											
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module					V																																																						
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																											
L	2006	ALL	Chassis	Traction Control Yes											V	V	V																																														
L	2006	ALL	Chassis	Traction Control No											V	V	V																																														
L	2006	ALL	Chassis	Electric Power Steering																																																											
L	2006	ALL	Body	Body Control Module																													V	V																													
L	2006	ALL	Body	Instrument Panel Cluster																																																											
L	2006	ALL	Body	Radio								V																																																			
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module					V																																																						
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																											
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																											
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control													V																																														
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control													V																																														
L	2007	ALL	Chassis	Power Steering Control Module																																																											
L	2007	ALL	Body	Body Control Module			V																													V			V																								
L	2007	ALL	Body	Digital Radio Receiver																																																											
L	2007	ALL	Body	Heated Seat Module																																																											
L	2007	ALL	Body	HVAC Control Module																																																											
L	2007	ALL	Body	Instrument Panel Cluster																																																											
L	2007	ALL	Body	Passenger Presence System																																																											
L	2007	ALL	Body	Radio																																																											
L	2007	ALL	Body	Rollover Sensor																																																											
L	2007	ALL	Body	Supplemental Inflatable Restraint																			V																																								
L	2007	ALL	Body	Theft Deterrent Module		V																																																										
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module					V																																																						
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																											
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																																						
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module													V																																												
L	2008	Captiva Sport	Body	Body Control Module			V																													V																										
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																									
L	2008	Captiva Sport	Body	HVAC Control Module Auto																																																									
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																																									
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																																									
L	2008	Captiva Sport	Body	Passenger Presence System																																																									
L	2008	Captiva Sport	Body	Radio																																																									
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																																									
L	2008	Captiva Sport	Body	Rollover Sensor																																																									
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																			V																																						
L	2008	Captiva Sport	Body	Theft Deterrent Module		V																																																								
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module					V																																															V			V
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																									
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																									
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																															V			V
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																									
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
L	2008	Equinox	Chassis	Electronic Brake Control Module													V																																												
L	2008	Equinox	Chassis	Power Steering Control Module																																																									
L	2008	Equinox	Body	Body Control Module			V																													V			V																						
L	2008	Equinox	Body	Digital Radio Receiver																																																									
L	2008	Equinox	Body	Heated Seat Module																																																									
L	2008	Equinox	Body	HVAC Control Module																																																									
L	2008	Equinox	Body	Instrument Panel Cluster																																																									
L	2008	Equinox	Body	Passenger Presence System																																																									
L	2008	Equinox	Body	Radio																																																									
L	2008	Equinox	Body	Rollover Sensor																																																									
L	2008	Equinox	Body	Supplemental Inflatable Restraint																			V																																						
L	2008	Equinox	Body	Theft Deterrent Module		V																																																								
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module					V																																															V			V
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																									
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module					V																																															V			V
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																									
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																															V				
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																									
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module													V																																												
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																									
L	2009	Captiva Sport	Body	Body Control Module			V																													V																										
L	2009	Captiva Sport	Body	HVAC Control Module Auto																																																									
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																																									
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																																									
L	2009	Captiva Sport	Body	Passenger Presence System																																																									
L	2009	Captiva Sport	Body	Radio																																																									
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																																									
L	2009	Captiva Sport	Body	Rollover Sensor																																																									
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																			V																																						
L	2009	Captiva Sport	Body	Theft Deterrent Module		V																																																								
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module					V																																															V			V

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																								
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																								
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																														V			V
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																							
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																							
L	2009	Equinox	Chassis	Electronic Brake Control Module													V																																										
L	2009	Equinox	Chassis	Power Steering Control Module																																																							
L	2009	Equinox	Body	Body Control Module			V																												V			V																						
L	2009	Equinox	Body	Digital Radio Receiver																																																							
L	2009	Equinox	Body	Heated Seat Module																																																							
L	2009	Equinox	Body	HVAC Control Module																																																							
L	2009	Equinox	Body	Instrument Panel Cluster																																																							
L	2009	Equinox	Body	Passenger Presence System																																																							
L	2009	Equinox	Body	Radio																																																							
L	2009	Equinox	Body	Rollover Sensor																																																							
L	2009	Equinox	Body	Supplemental Inflatable Restraint																			V																																					
L	2009	Equinox	Body	Theft Deterrent Module		V																																																						
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module					V																																														V			V
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																							
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																							
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module					V																																														V			V
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																							
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																							
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module					V																																														V			
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																							
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																							
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																							
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module													V																																										
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																							
L	2010	Captiva Sport	Body	Body Control Module			V																												V			V																						
L	2010	Captiva Sport	Body	HVAC Control Module																																																							
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																																							
L	2010	Captiva Sport	Body	Passenger Presence System																																																							
L	2010	Captiva Sport	Body	Radio																																																						
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																																						
L	2010	Captiva Sport	Body	Rollover Sensor																																																						
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																			V																																				
L	2010	Captiva Sport	Body	Theft Deterrent Module		V																																																					
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																						
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																						
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																						
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																						
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																						
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																						
L	2010	Equinox	Chassis	Electronic Brake Control Module																																																						
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																						
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																						
L	2010	Equinox	Body	Body Control Module																																																						
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
L	2010	Equinox	Body	Passenger Presence Module																																																						
L	2010	Equinox	Body	Instrument Cluster																																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2010	Equinox	Body	Radio																																																										
L	2010	Equinox	Body	Multimedia Player Interface Module																																																										
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2010	Equinox	Body	Liftgate Control Module																																																										
L	2010	Equinox	Body	Parking Assist Control Module																																																										
L	2010	Equinox	Body	Frontview Camera Module																																																										
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																																										
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
L	2011	Captiva	Chassis	Electronic Brake Control Module																																																										
L	2011	Captiva	Chassis	Parking Brake Control Module																																																										
L	2011	Captiva	Body	Body Control Module																																																										
L	2011	Captiva	Body	Auxiliary Body Control Module																																																										
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2011	Captiva	Body	Instrument Cluster																																																										
L	2011	Captiva	Body	Headlamp Control Module																																																										
L	2011	Captiva	Body	HVAC Control Module																																																										
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																										
L	2011	Captiva	Body	Parking Assist Control Module																																																										
L	2011	Captiva	Body	Theft Deterrent Module		V																																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module					V																																																					V
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module					V																																																					V
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module					V																																																					V
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module													V																																											
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																																									
L	2011	Captiva Sport	Body	Body Control Module			V																													V			V																							
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																									
L	2011	Captiva Sport	Body	HVAC Control Module																																																									
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																																									
L	2011	Captiva Sport	Body	Passenger Presence System																																																									
L	2011	Captiva Sport	Body	Radio																																																									
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																																									
L	2011	Captiva Sport	Body	Rollover Sensor																																																									
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																																																									
L	2011	Captiva Sport	Body	Theft Deterrent Module		V																																																							
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																																									
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																									
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																									
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																									
L	2011	Equinox	Chassis	Electronic Brake Control Module																																																									
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2011	Equinox	Body	Body Control Module																																																									
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2011	Equinox	Body	Passenger Presence Module																																																									
L	2011	Equinox	Body	Instrument Cluster																																																									
L	2011	Equinox	Body	Radio																																																									
L	2011	Equinox	Body	Multimedia Player Interface Module																																																									
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																									
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																									
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																																									
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																																									
L	2011	Equinox	Body	Liftgate Control Module																																																									
L	2011	Equinox	Body	Parking Assist Control Module																																																									
L	2011	Equinox	Body	Frontview Camera Module																																																									
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																																																									
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																									
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																									
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																									
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																									
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																									
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																									
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																									
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																									
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																									
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																									
L	2012	Captiva	Chassis	Electronic Brake Control Module																																																									
L	2012	Captiva	Chassis	Parking Brake Control Module																																																									
L	2012	Captiva	Body	Body Control Module																																																									
L	2012	Captiva	Body	Auxiliary Body Control Module																																																									
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2012	Captiva	Body	Instrument Cluster																																																									
L	2012	Captiva	Body	Headlamp Control Module																																																									
L	2012	Captiva	Body	HVAC Control Module																																																									
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																									
L	2012	Captiva	Body	Parking Assist Control Module																																																									
L	2012	Captiva	Body	Theft Deterrent Module		V																																																							
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module				V																																																					V
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																									
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																									
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																									
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module				V																																																					V
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																									
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																									
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																									
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module												V																																													
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																																									
L	2012	Captiva Sport	Body	Body Control Module			V																													V			V																						
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																									
L	2012	Captiva Sport	Body	HVAC Control Module																																																									
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																																									
L	2012	Captiva Sport	Body	Passenger Presence System																																																									
L	2012	Captiva Sport	Body	Radio																																																									
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																																									
L	2012	Captiva Sport	Body	Rollover Sensor																																																									
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																																																									
L	2012	Captiva Sport	Body	Theft Deterrent Module		V																																																							
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																									
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																									
L	2012	Equinox	Chassis	Electronic Brake Control Module																																																									
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2012	Equinox	Body	Body Control Module																																																									
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2012	Equinox	Body	Passenger Presence Module																																																									
L	2012	Equinox	Body	Instrument Cluster																																																									
L	2012	Equinox	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2012	Equinox	Body	Multimedia Player Interface Module																																																										
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2012	Equinox	Body	Liftgate Control Module																																																										
L	2012	Equinox	Body	Parking Assist Control Module																																																										
L	2012	Equinox	Body	Frontview Camera Module																																																										
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																																										
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																										
L	2013	Captiva	Chassis	Parking Brake Control Module																																																										
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																										
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																										
L	2013	Captiva	Body	Auxiliary Body Control Module																																																										
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2013	Captiva	Body	Instrument Cluster																																																										
L	2013	Captiva	Body	Headlamp Control Module																																																										
L	2013	Captiva	Body	HVAC Control Module																																																										
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																									V																	
L	2013	Captiva	Body	Theft Deterrent Module		V																																																								
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module					V																																																					V
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																										
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																										
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module					V																																																					V
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																										
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																										
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module													V																																												
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																										
L	2013	Captiva Sport	Body	Body Control Module			V																													V			V																							
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2013	Captiva Sport	Body	Heated Seat Module																																																										
L	2013	Captiva Sport	Body	HVAC Control Module																																																										
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2013	Captiva Sport	Body	Park Assist Module																																																											
L	2013	Captiva Sport	Body	Passenger Presence System																																																												
L	2013	Captiva Sport	Body	Radio																																																												
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																																												
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																												
L	2013	Captiva Sport	Body	Theft Deterrent Module		V																																																										
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2013	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2013	Equinox	Chassis	Power Steering Control Module																																																												
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																												
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2013	Equinox	Body	Passenger Presence Module																																																												
L	2013	Equinox	Body	Instrument Cluster																																																												
L	2013	Equinox	Body	Radio																																																												
L	2013	Equinox	Body	Rear Audio Control Module																																																												
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2013	Equinox	Body	Liftgate Control Module																																																												
L	2013	Equinox	Body	Front Seat Heating Control Module																																																												
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																												
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																												
L	2013	Equinox	Body	Parking Assist Control Module																																																												
L	2013	Equinox	Body	Frontview Camera Module																																																												
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																												
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																												
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																												
L	2014	Captiva (3GN)	Body	Body Control Module																																																												
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																												
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																												
L	2014	Captiva (3GN)	Body	Radio																																																												
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																												
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																												
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2014	Captiva (3GN)	Body	Theft Deterrent Module		V																																																								
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Captiva (Other)	Body	Instrument Cluster																																																										
L	2014	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2014	Captiva (Other)	Body	HVAC Control Module																																																										
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																										V																
L	2014	Captiva (Other)	Body	Theft Deterrent Module		V																																																								
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2014	Equinox	Chassis	Power Steering Control Module																																																										
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Equinox	Body	Passenger Presence Module																																																										
L	2014	Equinox	Body	Instrument Cluster																																																										
L	2014	Equinox	Body	Radio																																																										
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2014	Equinox	Body	Liftgate Control Module																																																										
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Parking Assist Control Module																																																										
L	2014	Equinox	Body	Frontview Camera Module																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (3GN)	Body	Body Control Module																																																										
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																																										
L	2015	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2015	Captiva (3GN)	Body	Radio																																																										
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
L	2015	Captiva (3GN)	Body	HVAC Control Module																																																										
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2015	Captiva (3GN)	Body	Theft Deterrent Module		V																																																								
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (Other)	Body	Instrument Cluster																																																										
L	2015	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2015	Captiva (Other)	Body	HVAC Control Module																																																										
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																										V														
L	2015	Captiva (Other)	Body	Theft Deterrent Module		V																																																						
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																								
L	2015	Equinox	Chassis	Electronic Brake Control Module																																																								
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2015	Equinox	Chassis	Power Steering Control Module																																																								
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																																								
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																								
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2015	Equinox	Body	Passenger Presence Module																																																								
L	2015	Equinox	Body	Instrument Cluster																																																								
L	2015	Equinox	Body	Radio																																																								
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																																								
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																																								
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																																								
L	2015	Equinox	Body	Liftgate Control Module																																																								
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																								
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																								
L	2015	Equinox	Body	Parking Assist Control Module																																																								
L	2015	Equinox	Body	Frontview Camera Module																																																								
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																								
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																								
L	2016	Captiva (3GN)	Body	Body Control Module																																																								
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2016	Captiva (3GN)	Body	Instrument Cluster																																																								
L	2016	Captiva (3GN)	Body	Radio																																																								
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																								
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																								
L	2016	Captiva (3GN)	Body	HVAC Control Module																																																								
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																								
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																								
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																								
L	2016	Captiva (3GN)	Body	Theft Deterrent Module		V																																																						
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																								
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																								
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																								
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																								
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Captiva (Other)	Body	Instrument Cluster																																																										
L	2016	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2016	Captiva (Other)	Body	Radio																																																										
L	2016	Captiva (Other)	Body	HVAC Control Module																																																										
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																										V																
L	2016	Captiva (Other)	Body	Theft Deterrent Module		V																																																								
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2016	Equinox	Chassis	Power Steering Control Module																																																										
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Equinox	Body	Passenger Presence Module																																																										
L	2016	Equinox	Body	Instrument Cluster																																																										
L	2016	Equinox	Body	Radio																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2016	Equinox	Body	Liftgate Control Module																																																										
L	2016	Equinox	Body	Seat Memory Control Module																																																										
L	2016	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Parking Assist Control Module																																																										
L	2016	Equinox	Body	Frontview Camera Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
M	2004	ALL	Chassis	4WAL 3 Sensor																																																										
M	2004	ALL	Body	Body Control Module																													V																													
M	2004	ALL	Body	Instrument Panel Cluster																																																										
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
M	2005	ALL	Chassis	4WAL 3 Sensor																																																										
M	2005	ALL	Body	Body Control Module																													V																													
M	2005	ALL	Body	Instrument Panel Cluster																																																										
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module					V																																																					
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module					V																																																					
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module					V																																																					
P	2007	ALL	Body	Supplemental Inflatable Restraint	V																																																									
P	2007	ALL	Body	Theft Deterrent Module		V																																																								
R	2009	ALL	Powertrain	Engine Control Module					V																																																V					V
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2009	ALL	Powertrain	Transmission Control Module																																																										
R	2009	ALL	Chassis	Electronic Brake Control Module													V																																													
R	2009	ALL	Body	Body Control Module			V																													V																										
R	2009	ALL	Body	Digital Radio Receiver																																																										
R	2009	ALL	Body	Driver Door Switch																																																										
R	2009	ALL	Body	Heated Seat Module																																																										
R	2009	ALL	Body	HVAC Control Module Auto																																																										
R	2009	ALL	Body	HVAC Control Module Manual																																																										
R	2009	ALL	Body	Instrument Panel Cluster																																																										
R	2009	ALL	Body	Lift Gate Module																																																										
R	2009	ALL	Body	Park Assist Module																																																										
R	2009	ALL	Body	Passenger Door Switch																																																										
R	2009	ALL	Body	Passenger Presence System																																																										
R	2009	ALL	Body	Radio																																																										
R	2009	ALL	Body	Rear HVAC/RSA																																																										
R	2009	ALL	Body	Rollover Sensor																																																										
R	2009	ALL	Body	Supplemental Inflatable Restraint																			V																																							
R	2009	ALL	Body	Theft Deterrent Module		V																																																								
R	2010	ALL	Powertrain	Engine Control Module					V																																																					V
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2010	ALL	Powertrain	Transmission Control Module																																																										
R	2010	ALL	Chassis	Electronic Brake Control Module													V																																													
R	2010	ALL	Body	Body Control Module			V																													V			V																							
R	2010	ALL	Body	Digital Radio Receiver																																																										
R	2010	ALL	Body	Driver Door Switch																																																										
R	2010	ALL	Body	Heated Seat Module																																																										
R	2010	ALL	Body	HVAC Control Module Auto																																																										
R	2010	ALL	Body	HVAC Control Module Manual																																																										
R	2010	ALL	Body	Instrument Panel Cluster																																																										
R	2010	ALL	Body	Lift Gate Module																																																										
R	2010	ALL	Body	Park Assist Module																																																										
R	2010	ALL	Body	Passenger Door Switch																																																										
R	2010	ALL	Body	Passenger Presence System																																																										
R	2010	ALL	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2010	ALL	Body	Rear HVAC/RSA																																																								
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2010	ALL	Body	Theft Deterrent Module		V																																																						
R	2011	ALL	Powertrain	Engine Control Module					V																																																			V
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2011	ALL	Powertrain	Transmission Control Module																																																								
R	2011	ALL	Chassis	Electronic Brake Control Module													V																																											
R	2011	ALL	Body	Body Control Module			V																													V			V																					
R	2011	ALL	Body	Digital Radio Receiver																																																								
R	2011	ALL	Body	Driver Door Switch																																																								
R	2011	ALL	Body	Heated Seat Module																																																								
R	2011	ALL	Body	HVAC Control Module Auto																																																								
R	2011	ALL	Body	HVAC Control Module Manual																																																								
R	2011	ALL	Body	Instrument Panel Cluster																																																								
R	2011	ALL	Body	Lift Gate Module																																																								
R	2011	ALL	Body	Park Assist Module																																																								
R	2011	ALL	Body	Passenger Door Switch																																																								
R	2011	ALL	Body	Passenger Presence System																																																								
R	2011	ALL	Body	Radio																																																								
R	2011	ALL	Body	Rear HVAC/RSA																																																								
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2011	ALL	Body	Theft Deterrent Module		V																																																						
R	2012	ALL	Powertrain	Engine Control Module					V																																																			V
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2012	ALL	Powertrain	Transmission Control Module																																																								
R	2012	ALL	Chassis	Electronic Brake Control Module													V																																											
R	2012	ALL	Body	Body Control Module			V																													V			V																					
R	2012	ALL	Body	Digital Radio Receiver																																																								
R	2012	ALL	Body	Driver Door Switch																																																								
R	2012	ALL	Body	Heated Seat Module																																																								
R	2012	ALL	Body	HVAC Control Module Auto																																																								
R	2012	ALL	Body	HVAC Control Module Manual																																																								
R	2012	ALL	Body	Instrument Panel Cluster																																																								
R	2012	ALL	Body	Lift Gate Module																																																								
R	2012	ALL	Body	Park Assist Module																																																								
R	2012	ALL	Body	Passenger Door Switch																																																								
R	2012	ALL	Body	Passenger Presence System																																																								
R	2012	ALL	Body	Radio																																																								
R	2012	ALL	Body	Rear HVAC/RSA																																																								
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2012	ALL	Body	Theft Deterrent Module		V																																																						
R	2013	ALL	Powertrain	Engine Control Module					V																																																			V
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2013	ALL	Powertrain	Transmission Control Module																																																								
R	2013	ALL	Chassis	Electronic Brake Control Module													V																																											
R	2013	ALL	Body	Body Control Module			V																													V			V																					
R	2013	ALL	Body	Digital Radio Receiver																																																								
R	2013	ALL	Body	Driver Door Switch																																																								
R	2013	ALL	Body	Heated Seat Module																																																								
R	2013	ALL	Body	HVAC Control Module Auto																																																								
R	2013	ALL	Body	HVAC Control Module Manual																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2013	ALL	Body	Instrument Panel Cluster																																																										
R	2013	ALL	Body	Left Side Object Detection Module																																																										
R	2013	ALL	Body	Lift Gate Module																																																										
R	2013	ALL	Body	Park Assist Module																																																										
R	2013	ALL	Body	Passenger Door Switch																																																										
R	2013	ALL	Body	Passenger Presence System																																																										
R	2013	ALL	Body	Radio																																																										
R	2013	ALL	Body	Rear HVAC/RSA																																																										
R	2013	ALL	Body	Right Side Object Detection Module																																																										
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2013	ALL	Body	Theft Deterrent Module		V																																																								
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2014	Traverse	Powertrain	Chassis Control Module																																																										
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2014	Traverse	Chassis	Electronic Brake Control Module																																																										
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2014	Traverse	Body	Passenger Presence Module																																																										
R	2014	Traverse	Body	Instrument Cluster																																																										
R	2014	Traverse	Body	Radio																																																										
R	2014	Traverse	Body	Rear Audio Control Module																																																										
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																										
R	2014	Traverse	Body	Personal Audio Link Control Module																																																										
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																										
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
R	2014	Traverse	Body	Liftgate Control Module																																																										
R	2014	Traverse	Body	Seat Memory Control Module																																																										
R	2014	Traverse	Body	Front Seat Heating Control Module																																																										
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2014	Traverse	Body	Parking Assist Control Module																																																										
R	2014	Traverse	Body	Frontview Camera Module																																																										
R	2014	Traverse	Body	Theft Deterrent Module		V																																																								
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2015	Traverse	Chassis	Electronic Brake Control Module																																																										
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	Traverse	Body	Passenger Presence Module																																																										
R	2015	Traverse	Body	Instrument Cluster																																																										
R	2015	Traverse	Body	Radio																																																										
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2015	Traverse	Body	Liftgate Control Module																																																										
R	2015	Traverse	Body	Seat Memory Control Module																																																										
R	2015	Traverse	Body	Front Seat Heating Control Module																																																										
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2015	Traverse	Body	Parking Assist Control Module																																																										
R	2015	Traverse	Body	Frontview Camera Module																																																										
R	2015	Traverse	Body	Theft Deterrent Module		V																																																								
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2016	Traverse	Chassis	Electronic Brake Control Module																																																										
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Traverse	Body	Passenger Presence Module																																																										
R	2016	Traverse	Body	Instrument Cluster																																																										
R	2016	Traverse	Body	Radio																																																										
R	2016	Traverse	Body	Rear Audio Control Module																																																										
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																										
R	2016	Traverse	Body	Personal Audio Link Control Module																																																										
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																										
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Traverse	Body	Liftgate Control Module																																																										
R	2016	Traverse	Body	Seat Memory Control Module																																																										
R	2016	Traverse	Body	Front Seat Heating Control Module																																																										
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2016	Traverse	Body	Parking Assist Control Module																																																										
R	2016	Traverse	Body	Frontview Camera Module																																																										
R	2016	Traverse	Body	Theft Deterrent Module		V																																																								
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	S10	Chassis	4WAL 3 Sensor																																																										
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																										
S	2004	S10	Body	Body Control Module																												V																														
S	2004	S10	Body	Instrument Panel Cluster																																																										
S	2004	S10	Body	Base Radio																																																										
S	2004	S10	Body	Uplevel Radio																																																										
S	2004	S10	Body	Supplemental Inflatable Restraint																																																										
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module			V		V																																																					
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module			V		V																																																				
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2004	Colorado	Chassis	ABS Without Traction Control																																																										
S	2004	Colorado	Chassis	ABS With Traction Control																																																										
S	2004	Colorado	Body	Body Control Module																												V												V																		
S	2004	Colorado	Body	Instrument Panel Cluster																																																										
S	2004	Colorado	Body	OnStar																																															V	V								
S	2004	Colorado	Body	Base Radio																																																										
S	2004	Colorado	Body	Uplevel Radio																																																										
S	2004	Colorado	Body	Supplemental Inflatable Restraint	V																																																									
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																										
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																										
S	2004	TrailBlazer	Body	Body Control Module																																																										
S	2004	TrailBlazer	Body	Driver Door Module																																																										
S	2004	TrailBlazer	Body	Driver Seat Module																			V																																								
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																			V																																								
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																																										
S	2004	TrailBlazer	Body	Lift Gate Module																																																										
S	2004	TrailBlazer	Body	OnStar																																															V	V								
S	2004	TrailBlazer	Body	Passenger Door Module																																																										
S	2004	TrailBlazer	Body	Uplevel Radio																																																										
S	2004	TrailBlazer	Body	Navigation Radio								V																																																		
S	2004	TrailBlazer	Body	Rear Seat Audio																																																										
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																										
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent		V																																																								
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module			V	V	V																																																					
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																										
S	2004	TrailBlazer EXT	Body	Body Control Module																																																										
S	2004	TrailBlazer EXT	Body	Driver Door Module																																																										
S	2004	TrailBlazer EXT	Body	Driver Seat Module																			V																																								
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																			V																																								
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																										
S	2004	TrailBlazer EXT	Body	OnStar																																															V	V								
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																																										
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																										
S	2004	TrailBlazer EXT	Body	Navigation Radio								V																																																		
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																										
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent		V																																																								
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																										
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Blazer	Body	Body Control Module																												V																														
S	2004	Blazer	Body	Heating and Air Conditioning																																																										
S	2004	Blazer	Body	Instrument Panel Cluster																																																										
S	2004	Blazer	Body	Memory Seat Module																																																										
S	2004	Blazer	Body	Base Radio																																																										
S	2004	Blazer	Body	Uplevel Radio																																																										
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																																										
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module			V	V	V																																																					
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	SSR	Chassis	4WAL 3 Sensor																																																										
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																										
S	2004	SSR	Body	Amplifier (Bose)																																																										
S	2004	SSR	Body	Body Control Module																												V																														
S	2004	SSR	Body	Driver Seat Module																			V																																							
S	2004	SSR	Body	Instrument Panel Cluster																																																										
S	2004	SSR	Body	Uplevel Radio																																																										
S	2004	SSR	Body	Remote Function Actuation																																																										
S	2004	SSR	Body	Roof and Door Module																																																										
S	2004	SSR	Body	Supplemental Inflatable Restraint																																																										
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module			V		V																																																					
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module			V		V																																																					
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2005	Colorado	Chassis	ABS Without Traction Control																																																										
S	2005	Colorado	Chassis	ABS With Traction Control																																																										
S	2005	Colorado	Body	Body Control Module																												V												V																		
S	2005	Colorado	Body	Instrument Panel Cluster																																																										
S	2005	Colorado	Body	Base Radio																																																										
S	2005	Colorado	Body	Uplevel Radio																																																										
S	2005	Colorado	Body	Supplemental Inflatable Restraint	V																																																									
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																															V	V	V									
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																										
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
S	2005	TrailBlazer	Body	Body Control Module																																																										
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2005	TrailBlazer	Body	Driver Door Module																																																										
S	2005	TrailBlazer	Body	Driver Seat Module																			V																																							
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																			V																																							
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2005	TrailBlazer	Body	Lift Gate Module																																																								
S	2005	TrailBlazer	Body	Passenger Door Module																																																								
S	2005	TrailBlazer	Body	Passenger Presence System																																																								
S	2005	TrailBlazer	Body	Uplevel Radio																																																								
S	2005	TrailBlazer	Body	Navigation Radio								V																																															
S	2005	TrailBlazer	Body	Rear Seat Audio																																																								
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint	V																																																							
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																															V	V	V						
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent		V																																																						
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																			
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																		
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																								
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																								
S	2005	TrailBlazer EXT	Body	Body Control Module																																																								
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																								
S	2005	TrailBlazer EXT	Body	Driver Door Module																																																								
S	2005	TrailBlazer EXT	Body	Driver Seat Module																			V																																					
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																			V																																					
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																								
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																								
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																								
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																																								
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																								
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																								
S	2005	TrailBlazer EXT	Body	Navigation Radio								V																																															
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																								
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																								
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																								
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint	V																																																							
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																															V	V	V						
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent		V																																																						
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																			
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																								
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																								
S	2005	Blazer	Body	Body Control Module																												V																											
S	2005	Blazer	Body	Heating and Air Conditioning																																																								
S	2005	Blazer	Body	Instrument Panel Cluster																																																								
S	2005	Blazer	Body	Memory Seat Module																																																								
S	2005	Blazer	Body	Base Radio																																																								
S	2005	Blazer	Body	Uplevel Radio																																																								
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																																								
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module			V		V																																																			
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
S	2005	SSR	Chassis	4WAL 3 Sensor																																																								
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																								
S	2005	SSR	Body	Amplifier (Bose)																																																								
S	2005	SSR	Body	Body Control Module																												V																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2005	SSR	Body	Driver Seat Module																			V																																							
S	2005	SSR	Body	Instrument Panel Cluster																																																										
S	2005	SSR	Body	Uplevel Radio																																																										
S	2005	SSR	Body	Remote Function Actuation																																																										
S	2005	SSR	Body	Roof and Door Module																																																										
S	2005	SSR	Body	Supplemental Inflatable Restraint																																																										
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module			V		V																																																					
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module			V		V																																																					
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2006	Colorado	Chassis	ABS Without Traction Control																																																										
S	2006	Colorado	Chassis	ABS With Traction Control																																																										
S	2006	Colorado	Body	Body Control Module																												V												V																		
S	2006	Colorado	Body	Instrument Panel Cluster																																																										
S	2006	Colorado	Body	Passenger Presence System																																																										
S	2006	Colorado	Body	Base Radio																																																										
S	2006	Colorado	Body	Uplevel Radio																																																										
S	2006	Colorado	Body	Supplemental Inflatable Restraint	V																																																									
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																																V	V	V							
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																					
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module			V		V																																																					
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																										
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																										
S	2006	TrailBlazer	Body	Body Control Module																												V																														
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2006	TrailBlazer	Body	Driver Door Module																																																										
S	2006	TrailBlazer	Body	Driver Seat Module																			V																																							
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																			V																																							
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																																										
S	2006	TrailBlazer	Body	Lift Gate Module																																																										
S	2006	TrailBlazer	Body	Passenger Door Module																																																										
S	2006	TrailBlazer	Body	Passenger Presence System																																																										
S	2006	TrailBlazer	Body	Uplevel Radio																																																										
S	2006	TrailBlazer	Body	Navigation Radio								V																																																	
S	2006	TrailBlazer	Body	Rear Seat Audio																																																										
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint	V																																																									
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent		V																																																								
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																V	V	V							
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																					
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																										
S	2006	TrailBlazer EXT	Body	Body Control Module																												V																														
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
S	2006	TrailBlazer EXT	Body	Driver Door Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2006	TrailBlazer EXT	Body	Driver Seat Module																			V																																							
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																			V																																							
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																										
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																																										
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																										
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																										
S	2006	TrailBlazer EXT	Body	Navigation Radio								V																																																	
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																										
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint	V																																																									
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent		V																																																								
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																V	V	V							
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module			V		V																																																					
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2006	SSR	Chassis	4WAL 3 Sensor																																																										
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																										
S	2006	SSR	Body	Amplifier (Bose)																																																										
S	2006	SSR	Body	Body Control Module																												V																														
S	2006	SSR	Body	Driver Seat Module																			V																																							
S	2006	SSR	Body	Instrument Panel Cluster																																																										
S	2006	SSR	Body	Uplevel Radio																																																										
S	2006	SSR	Body	Remote Function Actuation																																																										
S	2006	SSR	Body	Roof and Door Module																																																										
S	2006	SSR	Body	Supplemental Inflatable Restraint	V																																																									
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module			V		V																																																					
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module			V		V																																																					
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																										
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																										
S	2007	Colorado	Body	Body Control Module																												V												V		V															
S	2007	Colorado	Body	Digital Radio Receiver																																																										
S	2007	Colorado	Body	Generator Battery Control Module																																																										
S	2007	Colorado	Body	Instrument Panel Cluster																																																										
S	2007	Colorado	Body	Passenger Presence System																																																										
S	2007	Colorado	Body	Base Radio																																																										
S	2007	Colorado	Body	Uplevel Radio																																																										
S	2007	Colorado	Body	Supplemental Inflatable Restraint	V																																																									
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																																V	V	V							
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module			V		V																																																				
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																										
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																															V			V
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																															V			V
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2007	Trailblazer	Body	Body Control Module																													V																												
S	2007	Trailblazer	Body	Digital Radio Receiver																																																									
S	2007	Trailblazer	Body	Disc Player and Video Display																																																									
S	2007	Trailblazer	Body	Driver Door Module																																																									
S	2007	Trailblazer	Body	Driver Seat Module																			V																																							
S	2007	Trailblazer	Body	Generator Battery Control Module																																																									
S	2007	Trailblazer	Body	HVAC Control Module Auto																			V										V																													
S	2007	Trailblazer	Body	HVAC Control Module Manual																																																									
S	2007	Trailblazer	Body	Instrument Panel Cluster																																																									
S	2007	Trailblazer	Body	Lift Gate Module																																											V														
S	2007	Trailblazer	Body	Passenger Door Module																																																									
S	2007	Trailblazer	Body	Passenger Presence System																																																									
S	2007	Trailblazer	Body	Uplevel Radio																																																									
S	2007	Trailblazer	Body	Navigation Radio								V																																																
S	2007	Trailblazer	Body	Rear Seat Audio																																																									
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint	V																																																								
S	2007	Trailblazer	Body	Theft Deterrent Module		V																																																							
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																															V	V	V						
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																															V		V
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																		V
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																								
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																								
S	2008	Colorado	Body	Body Control Module																																								V		V														
S	2008	Colorado	Body	Digital Radio Receiver																																																								
S	2008	Colorado	Body	Generator Battery Control Module																																																								
S	2008	Colorado	Body	Instrument Panel Cluster																																																								
S	2008	Colorado	Body	Passenger Presence System																																																								
S	2008	Colorado	Body	Base Radio																																																								
S	2008	Colorado	Body	Uplevel Radio																																																								
S	2008	Colorado	Body	Supplemental Inflatable Restraint	V																																																								
S	2008	Colorado	Body	Theft Deterrent Module		V																																																							
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																															V	V	V						
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module					V																																																			V
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																														V			V
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																														V			V
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																								
S	2008	TrailBlazer	Body	Body Control Module																													V																													
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																								
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																								
S	2008	TrailBlazer	Body	Driver Door Module																																																								
S	2008	TrailBlazer	Body	Driver Seat Module																			V																																						
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																								
S	2008	TrailBlazer	Body	HVAC Control Module Auto																			V										V																													
S	2008	TrailBlazer	Body	HVAC Control Module Manual																																																								
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																																								
S	2008	TrailBlazer	Body	Lift Gate Module																																											V														

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2008	TrailBlazer	Body	Passenger Door Module																																																										
S	2008	TrailBlazer	Body	Passenger Presence System																																																										
S	2008	TrailBlazer	Body	Uplevel Radio																																																										
S	2008	TrailBlazer	Body	Navigation Radio								V																																																		
S	2008	TrailBlazer	Body	Rear Seat Audio																																																										
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint	V																																																									
S	2008	TrailBlazer	Body	Theft Deterrent Module		V																																																								
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																V	V	V								
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																																V		V
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																				V	
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module					V																																																V			V
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
S	2009	Colorado	Chassis	Electronic Brake Control Module											V	V																																														
S	2009	Colorado	Body	Body Control Module																																									V		V															
S	2009	Colorado	Body	Digital Radio Receiver																																																										
S	2009	Colorado	Body	Generator Battery Control Module																																																										
S	2009	Colorado	Body	Instrument Panel Cluster																																																										
S	2009	Colorado	Body	Passenger Presence System																																																										
S	2009	Colorado	Body	Base Radio																																																										
S	2009	Colorado	Body	Uplevel Radio																																																										
S	2009	Colorado	Body	Supplemental Inflatable Restraint	V																																																									
S	2009	Colorado	Body	Theft Deterrent Module		V																																																								
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module					V																																																				V	
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																										
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																V			V
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																																V			V
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																										
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																										
S	2009	TrailBlazer	Body	Body Control Module																													V																													
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																										
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2009	TrailBlazer	Body	Driver Door Module																																																										
S	2009	TrailBlazer	Body	Driver Seat Module																			V																																							
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																										
S	2009	TrailBlazer	Body	HVAC Control Module Auto																			V										V																													
S	2009	TrailBlazer	Body	HVAC Control Module Manual																																																										
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																																										
S	2009	TrailBlazer	Body	Lift Gate Module																																											V															
S	2009	TrailBlazer	Body	Passenger Door Module																																																										
S	2009	TrailBlazer	Body	Passenger Presence System																																																										
S	2009	TrailBlazer	Body	Uplevel Radio																																																										
S	2009	TrailBlazer	Body	Navigation Radio								V																																																		

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2009	TrailBlazer	Body	Rear Seat Audio																																																												
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint	V																																																											
S	2009	TrailBlazer	Body	Theft Deterrent Module		V																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																																	V		V
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																						V	
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module					V																																																	V			V		
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
S	2010	ALL	Chassis	Electronic Brake Control Module											V	V																																																
S	2010	ALL	Body	Body Control Module																																									V		V																	
S	2010	ALL	Body	Digital Radio Receiver																																																												
S	2010	ALL	Body	Generator Battery Control Module																																																												
S	2010	ALL	Body	Instrument Panel Cluster																																																												
S	2010	ALL	Body	Passenger Presence System																																																												
S	2010	ALL	Body	Personal Audio Link Module																																																												
S	2010	ALL	Body	Base Radio																																																												
S	2010	ALL	Body	Uplevel Radio																																																												
S	2010	ALL	Body	Supplemental Inflatable Restraint	V																																																											
S	2010	ALL	Body	Theft Deterrent Module		V																																																										
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																V			V									
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																																	V		V
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																						V	
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module					V																																																	V			V		
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
S	2011	ALL	Chassis	Electronic Brake Control Module											V	V																																																
S	2011	ALL	Body	Body Control Module																																									V		V																	
S	2011	ALL	Body	Digital Radio Receiver																																																												
S	2011	ALL	Body	Generator Battery Control Module																																																												
S	2011	ALL	Body	Instrument Panel Cluster																																																												
S	2011	ALL	Body	Passenger Presence System																																																												
S	2011	ALL	Body	Personal Audio Link Module																																																												
S	2011	ALL	Body	Base Radio																																																												
S	2011	ALL	Body	Uplevel Radio																																																												
S	2011	ALL	Body	Supplemental Inflatable Restraint	V																																																											
S	2011	ALL	Body	Theft Deterrent Module		V																																																										
S	2011	ALL	Body	Vehicle Comm. Interface Module																																																V			V									
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																																	V		V
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																						V	
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module					V																																																V			V
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																							
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																							
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module											V	V																																											
S	2012	Colorado (First Gen)	Body	Body Control Module																																								V		V													
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																						
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																						
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																						
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																						
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																						
S	2012	Colorado (First Gen)	Body	Base Radio																																																						
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																						
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint	V																																																					
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module		V																																																				
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																															V		V					
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																						
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																						
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																						
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																						
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																						
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																						
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																						
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																						
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																						
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																						
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																						
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																						
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																						
S	2012	Colorado (Second Gen)	Body	Body Control Module																																																						
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																						
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																						
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																						
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																						
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																						
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																						
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																						
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																						
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																						
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																						
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																						
S	2012	S10	Powertrain	Transfer Case Control Module																																																						
S	2012	S10	Chassis	Electronic Brake Control Module																																																						
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																						
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																						
S	2012	S10	Body	Body Control Module																																																						
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
S	2012	S10	Body	Instrument Cluster																																																						
S	2012	S10	Body	Trailer Interface Control Module																																																						
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																						
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																										
S	2013	Colorado	Powertrain	Transfer Case Control Module																																																										
S	2013	Colorado	Chassis	Electronic Brake Control Module																																																										
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2013	Colorado	Body	Body Control Module																																																										
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Colorado	Body	Instrument Cluster																																																										
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2013	S10	Powertrain	Transfer Case Control Module																																																										
S	2013	S10	Chassis	Electronic Brake Control Module																																																										
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2013	S10	Body	Body Control Module																																																										
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	S10	Body	Instrument Cluster																																																										
S	2013	S10	Body	Trailer Interface Control Module																																																										
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																										
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																										
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																										
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2013	Trailblazer	Body	Body Control Module																																																										
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Trailblazer	Body	Instrument Cluster																																																										
S	2013	Trailblazer	Body	Trailer Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2013	Trailblazer	Body	Parking Assist Control Module																																																								
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																								
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																								
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																								
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																								
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2014	Colorado	Body	Body Control Module																																																								
S	2014	Colorado	Body	Body Control Module																																																								
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2014	Colorado	Body	Instrument Cluster																																																								
S	2014	Colorado	Body	Radio																																																								
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																								
S	2014	Colorado	Body	Parking Assist Control Module																																																								
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2014	S10	Powertrain	Transfer Case Control Module																																																								
S	2014	S10	Chassis	Electronic Brake Control Module																																																								
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2014	S10	Body	Body Control Module																																																								
S	2014	S10	Body	Body Control Module																																																								
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2014	S10	Body	Instrument Cluster																																																								
S	2014	S10	Body	Trailer Interface Control Module																																																								
S	2014	S10	Body	Radio																																																								
S	2014	S10	Body	Parking Assist Control Module																																																								
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																								
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																								
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																										
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2014	Trailblazer	Body	Body Control Module																																																										
S	2014	Trailblazer	Body	Body Control Module																																																										
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Trailblazer	Body	Instrument Cluster																																																										
S	2014	Trailblazer	Body	Trailer Interface Control Module																																																										
S	2014	Trailblazer	Body	Parking Assist Control Module																																																										
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2015	Colorado	Powertrain	Chassis Control Module																																																										
S	2015	Colorado	Powertrain	Transfer Case Control Module																																																										
S	2015	Colorado	Chassis	Electronic Brake Control Module																																																										
S	2015	Colorado	Chassis	Power Steering Control Module																																																										
S	2015	Colorado	Body	Body Control Module																																																										
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Colorado	Body	Passenger Presence Module																																																										
S	2015	Colorado	Body	Radio																																																										
S	2015	Colorado	Body	Amplifier																																																										
S	2015	Colorado	Body	Human Machine Interface Control Module																																																										
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																																										
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																										
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																										
S	2015	Colorado	Body	Frontview Camera Module																																																										
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																										
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																										
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	Colorado (MMM)	Body	Body Control Module																																																										
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2015	Colorado (MMM)	Body	Instrument Cluster																																																									
S	2015	Colorado (MMM)	Body	Radio																																																									
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																									
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																									
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2015	S10	Powertrain	Transfer Case Control Module																																																									
S	2015	S10	Chassis	Electronic Brake Control Module																																																									
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2015	S10	Body	Body Control Module																																																									
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2015	S10	Body	Instrument Cluster																																																									
S	2015	S10	Body	Trailer Interface Control Module																																																									
S	2015	S10	Body	Radio																																																									
S	2015	S10	Body	Telematics Communication Interface Control Module																																																									
S	2015	S10	Body	Parking Assist Control Module																																																									
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																									
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																									
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2015	Trailblazer	Body	Body Control Module																																																									
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2015	Trailblazer	Body	Instrument Cluster																																																									
S	2015	Trailblazer	Body	Trailer Interface Control Module																																																									
S	2015	Trailblazer	Body	Radio																																																									
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																									
S	2015	Trailblazer	Body	Parking Assist Control Module																																																									
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																									
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																								
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																								
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																								
S	2016	Colorado (1GC)	Body	Body Control Module																																																								
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																																								
S	2016	Colorado (1GC)	Body	Radio Controls																																																								
S	2016	Colorado (1GC)	Body	HVAC Controls																																																								
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																								
S	2016	Colorado (1GC)	Body	Radio																																																								
S	2016	Colorado (1GC)	Body	Amplifier																																																								
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																								
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																								
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																								
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																								
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																								
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																																								
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																								
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																								
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2016	Colorado (MMM)	Body	Body Control Module																																																								
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2016	Colorado (MMM)	Body	Instrument Cluster																																																								
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																								
S	2016	Colorado (MMM)	Body	Radio																																																								
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																								
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																								
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																								
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																								
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																								
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
S	2016	S10	Powertrain	Transfer Case Control Module																																																								
S	2016	S10	Chassis	Electronic Brake Control Module																																																								
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2016	S10	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	S10	Body	Instrument Cluster																																																										
S	2016	S10	Body	Trailer Interface Control Module																																																										
S	2016	S10	Body	Radio																																																										
S	2016	S10	Body	Telematics Communication Interface Control Module																																																										
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																										
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																										
S	2016	S10	Body	Parking Assist Control Module																																																										
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																										
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																										
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	Trailblazer	Body	Body Control Module																																																										
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Trailblazer	Body	Instrument Cluster																																																										
S	2016	Trailblazer	Body	Trailer Interface Control Module																																																										
S	2016	Trailblazer	Body	Radio																																																										
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																										
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																										
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																										
S	2016	Trailblazer	Body	Parking Assist Control Module																																																										
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2004	S10	Chassis	4WAL 3 Sensor																																																										
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																										
T	2004	S10	Body	Body Control Module																													V																													
T	2004	S10	Body	Instrument Panel Cluster																																																										
T	2004	S10	Body	Base Radio																																																										
T	2004	S10	Body	Uplevel Radio																																																										
T	2004	S10	Body	Supplemental Inflatable Restraint																																																										
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module			V		V																																																					
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module			V		V																																																					
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2004	Colorado	Chassis	ABS Without Traction Control																																																										
T	2004	Colorado	Chassis	ABS With Traction Control																																																										
T	2004	Colorado	Body	Body Control Module																													V											V																		
T	2004	Colorado	Body	Instrument Panel Cluster																																																										
T	2004	Colorado	Body	OnStar																																																V	V								
T	2004	Colorado	Body	Base Radio																																																										
T	2004	Colorado	Body	Uplevel Radio																																																										
T	2004	Colorado	Body	Supplemental Inflatable Restraint	V																																																									
T	2004	Colorado	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																				
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer	Body	Body Control Module																																																										
T	2004	TrailBlazer	Body	Driver Door Module																																																										
T	2004	TrailBlazer	Body	Driver Seat Module																			V																																							
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																			V																																							
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2004	TrailBlazer	Body	Lift Gate Module																																																										
T	2004	TrailBlazer	Body	OnStar																																																V	V								
T	2004	TrailBlazer	Body	Passenger Door Module																																																										
T	2004	TrailBlazer	Body	Uplevel Radio																																																										
T	2004	TrailBlazer	Body	Navigation Radio								V																																																	
T	2004	TrailBlazer	Body	Rear Seat Audio																																																										
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent		V																																																								
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																				
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module			V	V	V																																																				
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer EXT	Body	Body Control Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Seat Module																			V																																							
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																			V																																							
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2004	TrailBlazer EXT	Body	OnStar																																																V	V								
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2004	TrailBlazer EXT	Body	Navigation Radio								V																																																	
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent		V																																																								
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																										
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Blazer	Body	Body Control Module																													V																													
T	2004	Blazer	Body	Heating and Air Conditioning																																																										
T	2004	Blazer	Body	Instrument Panel Cluster																																																										
T	2004	Blazer	Body	Memory Seat Module																																																										
T	2004	Blazer	Body	Base Radio																																																										
T	2004	Blazer	Body	Uplevel Radio																																																										
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																																										
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module			V		V																																																					
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module			V		V																																																					
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2005	Colorado	Chassis	ABS Without Traction Control																																																										
T	2005	Colorado	Chassis	ABS With Traction Control																																																										
T	2005	Colorado	Body	Body Control Module																													V												V																	
T	2005	Colorado	Body	Instrument Panel Cluster																																																										
T	2005	Colorado	Body	Base Radio																																																										
T	2005	Colorado	Body	Uplevel Radio																																																										
T	2005	Colorado	Body	Supplemental Inflatable Restraint	V																																																									
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																																V	V	V								
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																						
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable				V	V																																																					
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																										
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
T	2005	TrailBlazer	Body	Body Control Module																																																										
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2005	TrailBlazer	Body	Driver Door Module																																																										
T	2005	TrailBlazer	Body	Driver Seat Module																			V																																							
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																			V																																							
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2005	TrailBlazer	Body	Lift Gate Module																																																										
T	2005	TrailBlazer	Body	Passenger Door Module																																																										
T	2005	TrailBlazer	Body	Passenger Presence System																																																										
T	2005	TrailBlazer	Body	Uplevel Radio																																																										
T	2005	TrailBlazer	Body	Navigation Radio								V																																																		
T	2005	TrailBlazer	Body	Rear Seat Audio																																																										
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint	V																																																									
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																V	V	V								
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent		V																																																								
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																					
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																								
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																								
T	2005	TrailBlazer EXT	Body	Body Control Module																																																								
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																								
T	2005	TrailBlazer EXT	Body	Driver Door Module																																																								
T	2005	TrailBlazer EXT	Body	Driver Seat Module																			V																																					
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																			V																																					
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																								
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																								
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																								
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																																								
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																								
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																								
T	2005	TrailBlazer EXT	Body	Navigation Radio								V																																															
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																								
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																								
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																								
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint	V																																																							
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																															V	V	V						
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent		V																																																					
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																		
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																								
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																								
T	2005	Blazer	Body	Body Control Module																												V																												
T	2005	Blazer	Body	Heating and Air Conditioning																																																								
T	2005	Blazer	Body	Instrument Panel Cluster																																																								
T	2005	Blazer	Body	Memory Seat Module																																																								
T	2005	Blazer	Body	Base Radio																																																								
T	2005	Blazer	Body	Uplevel Radio																																																								
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																																								
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module			V		V																																																			
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																								
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module			V		V																																																			
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																								
T	2006	Colorado	Chassis	ABS Without Traction Control																																																								
T	2006	Colorado	Chassis	ABS With Traction Control																																																								
T	2006	Colorado	Body	Body Control Module																												V												V																
T	2006	Colorado	Body	Instrument Panel Cluster																																																								
T	2006	Colorado	Body	Passenger Presence System																																																								
T	2006	Colorado	Body	Base Radio																																																								
T	2006	Colorado	Body	Uplevel Radio																																																								
T	2006	Colorado	Body	Supplemental Inflatable Restraint	V																																																							
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																															V	V	V						
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																			
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																			
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																									
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module			V		V																																																				
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																										
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																										
T	2006	TrailBlazer	Body	Body Control Module																												V																														
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2006	TrailBlazer	Body	Driver Door Module																																																										
T	2006	TrailBlazer	Body	Driver Seat Module																			V																																							
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																			V																																							
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2006	TrailBlazer	Body	Lift Gate Module																																																										
T	2006	TrailBlazer	Body	Passenger Door Module																																																										
T	2006	TrailBlazer	Body	Passenger Presence System																																																										
T	2006	TrailBlazer	Body	Uplevel Radio																																																										
T	2006	TrailBlazer	Body	Navigation Radio								V																																																	
T	2006	TrailBlazer	Body	Rear Seat Audio																																																										
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint	V																																																									
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent		V																																																								
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																															V	V	V							
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																					
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																										
T	2006	TrailBlazer EXT	Body	Body Control Module																												V																														
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
T	2006	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2006	TrailBlazer EXT	Body	Driver Seat Module																			V																																							
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																			V																																							
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																										
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2006	TrailBlazer EXT	Body	Navigation Radio								V																																																	
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																										
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint	V																																																									
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent		V																																																								
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																															V	V	V							
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module			V		V																																																					
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module			V		V																																																				
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																										
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																										
T	2007	Colorado	Body	Body Control Module																												V												V		V																
T	2007	Colorado	Body	Digital Radio Receiver																																																										
T	2007	Colorado	Body	Generator Battery Control Module																																																										
T	2007	Colorado	Body	Instrument Panel Cluster																																																										
T	2007	Colorado	Body	Passenger Presence System																																																										
T	2007	Colorado	Body	Base Radio																																																										
T	2007	Colorado	Body	Uplevel Radio																																																										
T	2007	Colorado	Body	Supplemental Inflatable Restraint	V																																																									
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																																V	V	V								
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module			V		V																																																					
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																										
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																															V			V			
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																															V			V			
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																										
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2007	Trailblazer	Body	Body Control Module																												V																														
T	2007	Trailblazer	Body	Digital Radio Receiver																																																										
T	2007	Trailblazer	Body	Disc Player and Video Display																																																										
T	2007	Trailblazer	Body	Driver Door Module																																																										
T	2007	Trailblazer	Body	Driver Seat Module																			V																																							
T	2007	Trailblazer	Body	Generator Battery Control Module																																																										
T	2007	Trailblazer	Body	HVAC Control Module Auto																			V									V																														
T	2007	Trailblazer	Body	HVAC Control Module Manual																																																										
T	2007	Trailblazer	Body	Instrument Panel Cluster																																																										
T	2007	Trailblazer	Body	Lift Gate Module																																										V																
T	2007	Trailblazer	Body	Passenger Door Module																																																										
T	2007	Trailblazer	Body	Passenger Presence System																																																										
T	2007	Trailblazer	Body	Uplevel Radio																																																										
T	2007	Trailblazer	Body	Navigation Radio								V																																																		
T	2007	Trailblazer	Body	Rear Seat Audio																																																										
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint	V																																																									
T	2007	Trailblazer	Body	Theft Deterrent Module		V																																																								
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																V	V	V								
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																																V			V		
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																				V	
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2008	Colorado	Body	Body Control Module																																								V		V																

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2008	Colorado	Body	Digital Radio Receiver																																																								
T	2008	Colorado	Body	Generator Battery Control Module																																																								
T	2008	Colorado	Body	Instrument Panel Cluster																																																								
T	2008	Colorado	Body	Passenger Presence System																																																								
T	2008	Colorado	Body	Base Radio																																																								
T	2008	Colorado	Body	Uplevel Radio																																																								
T	2008	Colorado	Body	Supplemental Inflatable Restraint	V																																																							
T	2008	Colorado	Body	Theft Deterrent Module		V																																																						
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																															V	V	V							
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module					V																																																			V
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																								
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																														V			V
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																														V			V
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																								
T	2008	TrailBlazer	Body	Body Control Module																													V																											
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																								
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																								
T	2008	TrailBlazer	Body	Driver Door Module																																																								
T	2008	TrailBlazer	Body	Driver Seat Module																			V																																					
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																								
T	2008	TrailBlazer	Body	HVAC Control Module Auto																			V										V																											
T	2008	TrailBlazer	Body	HVAC Control Module Manual																																																								
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																																								
T	2008	TrailBlazer	Body	Lift Gate Module																																										V														
T	2008	TrailBlazer	Body	Passenger Door Module																																																								
T	2008	TrailBlazer	Body	Passenger Presence System																																																								
T	2008	TrailBlazer	Body	Uplevel Radio																																																								
T	2008	TrailBlazer	Body	Navigation Radio								V																																																
T	2008	TrailBlazer	Body	Rear Seat Audio																																																								
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint	V																																																							
T	2008	TrailBlazer	Body	Theft Deterrent Module		V																																																						
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																															V	V	V							
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																															V			V
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																			V
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module					V																																														V			V
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																								
T	2009	Colorado	Chassis	Electronic Brake Control Module										V	V																																													
T	2009	Colorado	Body	Body Control Module																																								V		V														
T	2009	Colorado	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2009	Colorado	Body	Generator Battery Control Module																																																								
T	2009	Colorado	Body	Instrument Panel Cluster																																																								
T	2009	Colorado	Body	Passenger Presence System																																																								
T	2009	Colorado	Body	Base Radio																																																								
T	2009	Colorado	Body	Uplevel Radio																																																								
T	2009	Colorado	Body	Supplemental Inflatable Restraint	V																																																								
T	2009	Colorado	Body	Theft Deterrent Module		V																																																							
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module					V																																																				V
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																									
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																															V			V
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																															V			V
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																									
T	2009	TrailBlazer	Body	Body Control Module																												V																														
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																									
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																									
T	2009	TrailBlazer	Body	Driver Door Module																																																									
T	2009	TrailBlazer	Body	Driver Seat Module																			V																																						
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																									
T	2009	TrailBlazer	Body	HVAC Control Module Auto																			V									V																													
T	2009	TrailBlazer	Body	HVAC Control Module Manual																																																									
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																																									
T	2009	TrailBlazer	Body	Lift Gate Module																																										V															
T	2009	TrailBlazer	Body	Passenger Door Module																																																									
T	2009	TrailBlazer	Body	Passenger Presence System																																																									
T	2009	TrailBlazer	Body	Uplevel Radio																																																									
T	2009	TrailBlazer	Body	Navigation Radio								V																																																
T	2009	TrailBlazer	Body	Rear Seat Audio																																																									
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint	V																																																								
T	2009	TrailBlazer	Body	Theft Deterrent Module		V																																																							
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																															V			V
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																			V
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module					V																																															V			V
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																									
T	2010	ALL	Chassis	Electronic Brake Control Module										V	V																																													
T	2010	ALL	Body	Body Control Module																																								V		V														
T	2010	ALL	Body	Digital Radio Receiver																																																									
T	2010	ALL	Body	Generator Battery Control Module																																																									
T	2010	ALL	Body	Instrument Panel Cluster																																																									
T	2010	ALL	Body	Passenger Presence System																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2010	ALL	Body	Personal Audio Link Module																																																									
T	2010	ALL	Body	Base Radio																																																									
T	2010	ALL	Body	Uplevel Radio																																																									
T	2010	ALL	Body	Supplemental Inflatable Restraint	V																																																									
T	2010	ALL	Body	Theft Deterrent Module		V																																																								
T	2010	ALL	Body	Vehicle Comm. Interface Module																																															V			V						
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																															V		V
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																			V
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module					V																																														V			V
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																								
T	2011	ALL	Chassis	Electronic Brake Control Module										V	V																																														
T	2011	ALL	Body	Body Control Module																																								V		V															
T	2011	ALL	Body	Digital Radio Receiver																																																								
T	2011	ALL	Body	Generator Battery Control Module																																																								
T	2011	ALL	Body	Instrument Panel Cluster																																																								
T	2011	ALL	Body	Passenger Presence System																																																								
T	2011	ALL	Body	Personal Audio Link Module																																																								
T	2011	ALL	Body	Base Radio																																																								
T	2011	ALL	Body	Uplevel Radio																																																								
T	2011	ALL	Body	Supplemental Inflatable Restraint	V																																																								
T	2011	ALL	Body	Theft Deterrent Module		V																																																							
T	2011	ALL	Body	Vehicle Comm. Interface Module																																															V			V						
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																														V		V
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																		V
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module					V																																														V			V
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																								
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module										V	V																																													
T	2012	Colorado (First Gen)	Body	Body Control Module																																								V		V															
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																								
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																								
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																								
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																								
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																								
T	2012	Colorado (First Gen)	Body	Base Radio																																																								
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint	V																																																									
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module		V																																																								
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																V			V						
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2012	Colorado (Second Gen)	Body	Body Control Module																																																										
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																										
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																										
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2012	S10	Powertrain	Transfer Case Control Module																																																										
T	2012	S10	Chassis	Electronic Brake Control Module																																																										
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2012	S10	Body	Body Control Module																																																										
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2012	S10	Body	Instrument Cluster																																																										
T	2012	S10	Body	Trailer Interface Control Module																																																										
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2013	Colorado	Powertrain	Transfer Case Control Module																																																										
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2013	Colorado	Body	Body Control Module																																																										
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	Colorado	Body	Instrument Cluster																																																										
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2013	S10	Powertrain	Transfer Case Control Module																																																										
T	2013	S10	Chassis	Electronic Brake Control Module																																																										
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2013	S10	Body	Body Control Module																																																										
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	S10	Body	Instrument Cluster																																																										
T	2013	S10	Body	Trailer Interface Control Module																																																										
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																										
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2013	Trailblazer	Body	Body Control Module																																																										
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	Trailblazer	Body	Instrument Cluster																																																										
T	2013	Trailblazer	Body	Trailer Interface Control Module																																																										
T	2013	Trailblazer	Body	Parking Assist Control Module																																																										
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2014	Colorado	Powertrain	Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	Colorado	Body	Body Control Module																																																										
T	2014	Colorado	Body	Body Control Module																																																										
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Colorado	Body	Instrument Cluster																																																										
T	2014	Colorado	Body	Radio																																																										
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																										
T	2014	Colorado	Body	Parking Assist Control Module																																																										
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2014	S10	Powertrain	Transfer Case Control Module																																																										
T	2014	S10	Chassis	Electronic Brake Control Module																																																										
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	S10	Body	Body Control Module																																																										
T	2014	S10	Body	Body Control Module																																																										
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	S10	Body	Instrument Cluster																																																										
T	2014	S10	Body	Trailer Interface Control Module																																																										
T	2014	S10	Body	Radio																																																										
T	2014	S10	Body	Parking Assist Control Module																																																										
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																										
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	Trailblazer	Body	Body Control Module																																																										
T	2014	Trailblazer	Body	Body Control Module																																																										
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Trailblazer	Body	Instrument Cluster																																																										
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																										
T	2014	Trailblazer	Body	Parking Assist Control Module																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2015	Colorado	Powertrain	Chassis Control Module																																																										
T	2015	Colorado	Powertrain	Transfer Case Control Module																																																										
T	2015	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2015	Colorado	Chassis	Power Steering Control Module																																																										
T	2015	Colorado	Body	Body Control Module																																																										
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Colorado	Body	Passenger Presence Module																																																										
T	2015	Colorado	Body	Radio																																																										
T	2015	Colorado	Body	Amplifier																																																										
T	2015	Colorado	Body	Human Machine Interface Control Module																																																										
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																																										
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																										
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																										
T	2015	Colorado	Body	Frontview Camera Module																																																										
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																										
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																										
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2015	Colorado (MMM)	Body	Body Control Module																																																										
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Colorado (MMM)	Body	Instrument Cluster																																																										
T	2015	Colorado (MMM)	Body	Radio																																																										
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																										
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	S10	Powertrain	Transfer Case Control Module																																																									
T	2015	S10	Chassis	Electronic Brake Control Module																																																									
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2015	S10	Body	Body Control Module																																																									
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	S10	Body	Instrument Cluster																																																									
T	2015	S10	Body	Trailer Interface Control Module																																																									
T	2015	S10	Body	Radio																																																									
T	2015	S10	Body	Telematics Communication Interface Control Module																																																									
T	2015	S10	Body	Parking Assist Control Module																																																									
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																									
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																									
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2015	Trailblazer	Body	Body Control Module																																																									
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Trailblazer	Body	Instrument Cluster																																																									
T	2015	Trailblazer	Body	Trailer Interface Control Module																																																									
T	2015	Trailblazer	Body	Radio																																																									
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																									
T	2015	Trailblazer	Body	Parking Assist Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																									
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																									
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																									
T	2016	Colorado (1GC)	Body	Body Control Module																																																									
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																																									
T	2016	Colorado (1GC)	Body	Radio Controls																																																									
T	2016	Colorado (1GC)	Body	HVAC Controls																																																									
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																									
T	2016	Colorado (1GC)	Body	Radio																																																									
T	2016	Colorado (1GC)	Body	Amplifier																																																									
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																										
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																										
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																										
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																										
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																										
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																										
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2016	Colorado (MMM)	Body	Body Control Module																																																										
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																										
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																										
T	2016	Colorado (MMM)	Body	Radio																																																										
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																										
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																										
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																										
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																										
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
T	2016	S10	Powertrain	Transfer Case Control Module																																																										
T	2016	S10	Chassis	Electronic Brake Control Module																																																										
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2016	S10	Body	Body Control Module																																																									
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	S10	Body	Instrument Cluster																																																										
T	2016	S10	Body	Trailer Interface Control Module																																																										
T	2016	S10	Body	Radio																																																										
T	2016	S10	Body	Telematics Communication Interface Control Module																																																										
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																										
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																										
T	2016	S10	Body	Parking Assist Control Module																																																										
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																										
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2016	Trailblazer	Body	Body Control Module																																																										
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Trailblazer	Body	Instrument Cluster																																																										
T	2016	Trailblazer	Body	Trailer Interface Control Module																																																										
T	2016	Trailblazer	Body	Radio																																																										
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																										
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																										
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																										
T	2016	Trailblazer	Body	Parking Assist Control Module																																																										
V	2009	ALL	Powertrain	Engine Control Module					V																																														V			V
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2009	ALL	Powertrain	Rear Drive System																																																										
V	2009	ALL	Powertrain	Transmission Control Module																																																										
V	2009	ALL	Chassis	Electronic Brake Control Module													V																																												
V	2009	ALL	Body	Body Control Module			V																													V																											
V	2009	ALL	Body	Digital Radio Receiver																																																										
V	2009	ALL	Body	Driver Door Switch																																																										
V	2009	ALL	Body	Heated Seat Module																																																										
V	2009	ALL	Body	HVAC Control Module Auto																																																										
V	2009	ALL	Body	HVAC Control Module Manual																																																										
V	2009	ALL	Body	Instrument Panel Cluster																																																										
V	2009	ALL	Body	Lift Gate Module																																																										
V	2009	ALL	Body	Park Assist Module																																																										
V	2009	ALL	Body	Passenger Door Switch																																																										
V	2009	ALL	Body	Passenger Presence System																																																										
V	2009	ALL	Body	Radio																																																										
V	2009	ALL	Body	Rear HVAC/RSA																																																										
V	2009	ALL	Body	Rollover Sensor																																																										
V	2009	ALL	Body	Supplemental Inflatable Restraint																			V																																							
V	2009	ALL	Body	Theft Deterrent Module		V																																																								
V	2010	ALL	Powertrain	Engine Control Module					V																																																				V
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2010	ALL	Powertrain	Rear Drive System																																																										
V	2010	ALL	Powertrain	Transmission Control Module																																																										
V	2010	ALL	Chassis	Electronic Brake Control Module													V																																												
V	2010	ALL	Body	Body Control Module			V																													V			V																						
V	2010	ALL	Body	Digital Radio Receiver																																																										
V	2010	ALL	Body	Driver Door Switch																																																										
V	2010	ALL	Body	Heated Seat Module																																																										
V	2010	ALL	Body	HVAC Control Module Auto																																																										
V	2010	ALL	Body	HVAC Control Module Manual																																																										
V	2010	ALL	Body	Instrument Panel Cluster																																																										
V	2010	ALL	Body	Lift Gate Module																																																										
V	2010	ALL	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
V	2010	ALL	Body	Passenger Door Switch																																																								
V	2010	ALL	Body	Passenger Presence System																																																								
V	2010	ALL	Body	Radio																																																								
V	2010	ALL	Body	Rear HVAC/RSA																																																								
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2010	ALL	Body	Theft Deterrent Module		V																																																							
V	2011	ALL	Powertrain	Engine Control Module					V																																																				V
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2011	ALL	Powertrain	Rear Drive System																																																								
V	2011	ALL	Powertrain	Transmission Control Module																																																								
V	2011	ALL	Chassis	Electronic Brake Control Module													V																																										
V	2011	ALL	Body	Body Control Module			V																													V			V																						
V	2011	ALL	Body	Digital Radio Receiver																																																								
V	2011	ALL	Body	Driver Door Switch																																																								
V	2011	ALL	Body	Heated Seat Module																																																								
V	2011	ALL	Body	HVAC Control Module Auto																																																								
V	2011	ALL	Body	HVAC Control Module Manual																																																								
V	2011	ALL	Body	Instrument Panel Cluster																																																								
V	2011	ALL	Body	Lift Gate Module																																																								
V	2011	ALL	Body	Park Assist Module																																																								
V	2011	ALL	Body	Passenger Door Switch																																																								
V	2011	ALL	Body	Passenger Presence System																																																								
V	2011	ALL	Body	Radio																																																								
V	2011	ALL	Body	Rear HVAC/RSA																																																								
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2011	ALL	Body	Theft Deterrent Module		V																																																							
V	2012	ALL	Powertrain	Engine Control Module					V																																																				V
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2012	ALL	Powertrain	Rear Drive System																																																								
V	2012	ALL	Powertrain	Transmission Control Module																																																								
V	2012	ALL	Chassis	Electronic Brake Control Module													V																																										
V	2012	ALL	Body	Body Control Module			V																													V			V																						
V	2012	ALL	Body	Digital Radio Receiver																																																								
V	2012	ALL	Body	Driver Door Switch																																																								
V	2012	ALL	Body	Heated Seat Module																																																								
V	2012	ALL	Body	HVAC Control Module Auto																																																								
V	2012	ALL	Body	HVAC Control Module Manual																																																								
V	2012	ALL	Body	Instrument Panel Cluster																																																								
V	2012	ALL	Body	Lift Gate Module																																																								
V	2012	ALL	Body	Park Assist Module																																																								
V	2012	ALL	Body	Passenger Door Switch																																																								
V	2012	ALL	Body	Passenger Presence System																																																								
V	2012	ALL	Body	Radio																																																								
V	2012	ALL	Body	Rear HVAC/RSA																																																								
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2012	ALL	Body	Theft Deterrent Module		V																																																						
V	2013	ALL	Powertrain	Engine Control Module					V																																																				V
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2013	ALL	Powertrain	Rear Drive System																																																								
V	2013	ALL	Powertrain	Transmission Control Module																																																								
V	2013	ALL	Chassis	Electronic Brake Control Module													V																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
V	2013	ALL	Body	Body Control Module			V																													V			V																					
V	2013	ALL	Body	Digital Radio Receiver																																																							
V	2013	ALL	Body	Driver Door Switch																																																							
V	2013	ALL	Body	Heated Seat Module																																																							
V	2013	ALL	Body	HVAC Control Module Auto																																																							
V	2013	ALL	Body	HVAC Control Module Manual																																																							
V	2013	ALL	Body	Instrument Panel Cluster																																																							
V	2013	ALL	Body	Left Side Object Detection Module																																																							
V	2013	ALL	Body	Lift Gate Module																																																							
V	2013	ALL	Body	Park Assist Module																																																							
V	2013	ALL	Body	Passenger Door Switch																																																							
V	2013	ALL	Body	Passenger Presence System																																																							
V	2013	ALL	Body	Radio																																																							
V	2013	ALL	Body	Rear HVAC/RSA																																																							
V	2013	ALL	Body	Right Side Object Detection Module																																																							
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																							
V	2013	ALL	Body	Theft Deterrent Module		V																																																					
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																							
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																							
V	2014	Traverse	Powertrain	Chassis Control Module																																																							
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																							
V	2014	Traverse	Chassis	Electronic Brake Control Module																																																							
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																							
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																							
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
V	2014	Traverse	Body	Passenger Presence Module																																																							
V	2014	Traverse	Body	Instrument Cluster																																																							
V	2014	Traverse	Body	Radio																																																							
V	2014	Traverse	Body	Rear Audio Control Module																																																							
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																							
V	2014	Traverse	Body	Personal Audio Link Control Module																																																							
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																							
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																							
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																							
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																							
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																							
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																							
V	2014	Traverse	Body	Liftgate Control Module																																																							
V	2014	Traverse	Body	Seat Memory Control Module																																																							
V	2014	Traverse	Body	Front Seat Heating Control Module																																																							
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																							
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																							
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																							
V	2014	Traverse	Body	Parking Assist Control Module																																																							
V	2014	Traverse	Body	Frontview Camera Module																																																							
V	2014	Traverse	Body	Theft Deterrent Module		V																																																					
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																							
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																							
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																							
V	2015	Traverse	Chassis	Electronic Brake Control Module																																																							
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Traverse	Body	Passenger Presence Module																																																										
V	2015	Traverse	Body	Instrument Cluster																																																										
V	2015	Traverse	Body	Radio																																																										
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2015	Traverse	Body	Liftgate Control Module																																																										
V	2015	Traverse	Body	Seat Memory Control Module																																																										
V	2015	Traverse	Body	Front Seat Heating Control Module																																																										
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2015	Traverse	Body	Parking Assist Control Module																																																										
V	2015	Traverse	Body	Frontview Camera Module																																																										
V	2015	Traverse	Body	Theft Deterrent Module		V																																																								
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Traverse	Chassis	Electronic Brake Control Module																																																										
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Traverse	Body	Passenger Presence Module																																																										
V	2016	Traverse	Body	Instrument Cluster																																																										
V	2016	Traverse	Body	Radio																																																										
V	2016	Traverse	Body	Rear Audio Control Module																																																										
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2016	Traverse	Body	Personal Audio Link Control Module																																																										
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																										
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Liftgate Control Module																																																										
V	2016	Traverse	Body	Seat Memory Control Module																																																										
V	2016	Traverse	Body	Front Seat Heating Control Module																																																										
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2016	Traverse	Body	Parking Assist Control Module																																																										
V	2016	Traverse	Body	Frontview Camera Module																																																										
V	2016	Traverse	Body	Theft Deterrent Module		V																																																								
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								V		
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								V		

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																											
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																											
A	2011	Orlando	Chassis	Parking Brake Control Module																																																											
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2011	Orlando	Chassis	Power Steering Control Module																																																											
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2011	Orlando	Body	Body Control Module																																																											
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2011	Orlando	Body	Instrument Cluster																																																											
A	2011	Orlando	Body	Trailer Interface Control Module																																																											
A	2011	Orlando	Body	Radio																																																											
A	2011	Orlando	Body	Multimedia Player Interface Module																																																											
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
A	2011	Orlando	Body	Keyless Entry Control Module																																																											
A	2011	Orlando	Body	Parking Assist Control Module																																																											
A	2011	Orlando	Body	Steering Column Lock Control Module																																																											
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																											
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																											
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																											
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																											
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																											
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																											
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																											
A	2012	Orlando	Chassis	Parking Brake Control Module																																																											
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2012	Orlando	Chassis	Power Steering Control Module																																																											
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2012	Orlando	Body	Body Control Module																																																											
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2012	Orlando	Body	Instrument Cluster																																																											
A	2012	Orlando	Body	Trailer Interface Control Module																																																											
A	2012	Orlando	Body	Radio																																																											
A	2012	Orlando	Body	Multimedia Player Interface Module																																																											
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
A	2012	Orlando	Body	Keyless Entry Control Module																																																											
A	2012	Orlando	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2012	Orlando	Body	Steering Column Lock Control Module																																																									
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission					V																																																				
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission					V																																																		V		
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																						V		
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																									
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																							V		
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																									
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																									
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																									
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																									
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																									
A	2013	Orlando	Chassis	Parking Brake Control Module																																																									
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2013	Orlando	Chassis	Power Steering Control Module																																																									
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2013	Orlando	Body	Body Control Module																																																								
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2013	Orlando	Body	Instrument Cluster																																																									
A	2013	Orlando	Body	Radio																																																									
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																									
A	2013	Orlando	Body	Multimedia Player Interface Module																																																									
A	2013	Orlando	Body	Mobile Telephone Control Module																																																									
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
A	2013	Orlando	Body	Front Seat Heating Control Module																																																									
A	2013	Orlando	Body	Keyless Entry Control Module																																																									
A	2013	Orlando	Body	Parking Assist Control Module																																																									
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission					V																																																				
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission					V																																																		V		
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission					V																																																				
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission					V																																																		V		
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																								V		
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								V		

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	Orlando	Chassis	Power Steering Control Module																																																										
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	Orlando	Body	Body Control Module																																																										
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	Orlando	Body	Instrument Cluster																																																										
A	2014	Orlando	Body	Radio																																																										
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2014	Orlando	Body	Multimedia Player Interface Module																																																										
A	2014	Orlando	Body	Mobile Telephone Control Module																																																										
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2014	Orlando	Body	Front Seat Heating Control Module																																																										
A	2014	Orlando	Body	Rear Seat Heating Control Module																																																										
A	2014	Orlando	Body	Keyless Entry Control Module																																																										
A	2014	Orlando	Body	Parking Assist Control Module																																																										
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission					V																																																					
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission					V																																																		V		
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																						V		
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	Orlando	Chassis	Power Steering Control Module																																																										
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	Orlando	Body	Body Control Module																																																										
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	Orlando	Body	Instrument Cluster																																																										
A	2015	Orlando	Body	Radio																																																										
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2015	Orlando	Body	Mobile Telephone Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																										
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2015	Orlando	Body	Front Seat Heating Control Module																																																										
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																										
A	2015	Orlando	Body	Keyless Entry Control Module																																																										
A	2015	Orlando	Body	Parking Assist Control Module																																																										
A	2015	Orlando	Body	Frontview Camera Module																																																										
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission					V																																																					
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission					V																																																		V		
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																										
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																								V		
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																										
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2016	Orlando	Chassis	Power Steering Control Module																																																										
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	Orlando	Body	Body Control Module																																																										
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	Orlando	Body	Instrument Cluster																																																										
A	2016	Orlando	Body	Radio																																																										
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2016	Orlando	Body	Multimedia Player Interface Module																																																										
A	2016	Orlando	Body	Mobile Telephone Control Module																																																										
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																										
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2016	Orlando	Body	Front Seat Heating Control Module																																																										
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																										
A	2016	Orlando	Body	Keyless Entry Control Module																																																										
A	2016	Orlando	Body	Parking Assist Control Module																																																										
A	2016	Orlando	Body	Frontview Camera Module																																																										
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2009	N200	Chassis	Electronic Brake Control Module																																																										
C	2009	N200	Body	Supplemental Inflatable Restraint																																																										
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2009	N300	Chassis	Electronic Brake Control Module																																																										
C	2009	N300	Body	Supplemental Inflatable Restraint																																																										
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2010	N200	Chassis	Electronic Brake Control Module																																																										
C	2010	N200	Body	Supplemental Inflatable Restraint																																																										
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2010	N300	Chassis	Electronic Brake Control Module																																																										
C	2010	N300	Body	Supplemental Inflatable Restraint																																																										
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2011	N200	Chassis	Electronic Brake Control Module																																																										
C	2011	N200	Body	Supplemental Inflatable Restraint																																																										
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2011	N300	Chassis	Electronic Brake Control Module																																																										
C	2011	N300	Body	Supplemental Inflatable Restraint																																																										
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2012	N200	Chassis	Electronic Brake Control Module																																																										
C	2012	N200	Body	Supplemental Inflatable Restraint																																																										
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2012	N300	Chassis	Electronic Brake Control Module																																																										
C	2012	N300	Body	Supplemental Inflatable Restraint																																																										
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2013	N300	Chassis	Electronic Brake Control Module																																																										
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																																										
C	2014	N300	Chassis	Electronic Brake Control Module																																																										
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																																										
C	2015	Max	Chassis	Electronic Brake Control Module																																																										
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																																										
C	2015	Move	Chassis	Electronic Brake Control Module																																																										
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																																										
C	2015	N300	Chassis	Electronic Brake Control Module																																																										
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																																										
C	2016	Max	Chassis	Electronic Brake Control Module																																																										
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																																										
C	2016	Move	Chassis	Electronic Brake Control Module																																																										
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																																										
C	2016	N300	Chassis	Electronic Brake Control Module																																																										
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																										
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																										
M	2015	City Express	Chassis	Electronic Brake Control Module																																																										
M	2015	City Express	Chassis	Power Steering Control Module																																																										
M	2015	City Express	Body	Body Control Module																																																										
M	2015	City Express	Body	Underhood Fuse Block																																																										
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	City Express	Body	Instrument Cluster																																																										
M	2015	City Express	Body	Tire Pressure Indicator Module																																																										
M	2015	City Express	Body	Radio																																																										
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																										
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																										
M	2016	City Express	Chassis	Electronic Brake Control Module																																																										
M	2016	City Express	Chassis	Power Steering Control Module																																																										
M	2016	City Express	Body	Body Control Module																																																										
M	2016	City Express	Body	Underhood Fuse Block																																																										
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	City Express	Body	Instrument Cluster																																																										
M	2016	City Express	Body	Tire Pressure Indicator Module																																																										
M	2016	City Express	Body	Radio																																																										
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									V		
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								V		
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2011	Orlando	Chassis	Parking Brake Control Module																																																										
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2011	Orlando	Chassis	Power Steering Control Module																																																										
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
P	2011	Orlando	Body	Body Control Module																																																										
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2011	Orlando	Body	Instrument Cluster																																																										
P	2011	Orlando	Body	Trailer Interface Control Module																																																										
P	2011	Orlando	Body	Radio																																																										
P	2011	Orlando	Body	Multimedia Player Interface Module																																																										
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
P	2011	Orlando	Body	Keyless Entry Control Module																																																										
P	2011	Orlando	Body	Parking Assist Control Module																																																										
P	2011	Orlando	Body	Steering Column Lock Control Module																																																										
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									V	
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									V	
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																										
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																										
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																										
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																										
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2012	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2012	Orlando	Chassis	Parking Brake Control Module																																																										
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2012	Orlando	Chassis	Power Steering Control Module																																																										
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2012	Orlando	Body	Body Control Module																																																										
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2012	Orlando	Body	Instrument Cluster																																																										
P	2012	Orlando	Body	Trailer Interface Control Module																																																										
P	2012	Orlando	Body	Radio																																																										
P	2012	Orlando	Body	Multimedia Player Interface Module																																																										
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
P	2012	Orlando	Body	Keyless Entry Control Module																																																										
P	2012	Orlando	Body	Parking Assist Control Module																																																										
P	2012	Orlando	Body	Steering Column Lock Control Module																																																										
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission					V																																																					
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission					V																																																				V	
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																									V	
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																									
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																							V		
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																									
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2013	Orlando	Chassis	Parking Brake Control Module																																																									
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2013	Orlando	Chassis	Power Steering Control Module																																																									
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2013	Orlando	Body	Body Control Module																																																									
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2013	Orlando	Body	Instrument Cluster																																																									
P	2013	Orlando	Body	Radio																																																									
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																									
P	2013	Orlando	Body	Multimedia Player Interface Module																																																									
P	2013	Orlando	Body	Mobile Telephone Control Module																																																									
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
P	2013	Orlando	Body	Front Seat Heating Control Module																																																									
P	2013	Orlando	Body	Keyless Entry Control Module																																																									
P	2013	Orlando	Body	Parking Assist Control Module																																																									
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission					V																																																				
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission					V																																																	V		
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission					V																																																				
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission					V																																																	V		
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																							V		
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																							V		
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																									
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
P	2014	Orlando	Chassis	Power Steering Control Module																																																										
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2014	Orlando	Body	Body Control Module																																																										
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2014	Orlando	Body	Instrument Cluster																																																										
P	2014	Orlando	Body	Radio																																																										
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																										
P	2014	Orlando	Body	Multimedia Player Interface Module																																																										
P	2014	Orlando	Body	Mobile Telephone Control Module																																																										
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
P	2014	Orlando	Body	Front Seat Heating Control Module																																																										
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																										
P	2014	Orlando	Body	Keyless Entry Control Module																																																										
P	2014	Orlando	Body	Parking Assist Control Module																																																										
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission					V																																																					
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission					V																																																		V		
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																							V		
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								V		
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2015	Orlando	Chassis	Power Steering Control Module																																																										
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2015	Orlando	Body	Body Control Module																																																										
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2015	Orlando	Body	Instrument Cluster																																																										
P	2015	Orlando	Body	Radio																																																										
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																										
P	2015	Orlando	Body	Mobile Telephone Control Module																																																										
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																										
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
P	2015	Orlando	Body	Front Seat Heating Control Module																																																										
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																										
P	2015	Orlando	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
P	2015	Orlando	Body	Parking Assist Control Module																																																										
P	2015	Orlando	Body	Frontview Camera Module																																																										
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission					V																																																					
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission					V																																																		V		
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																									
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																									
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																							V		
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																									
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																									
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2016	Orlando	Chassis	Power Steering Control Module																																																									
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2016	Orlando	Body	Body Control Module																																																									
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2016	Orlando	Body	Instrument Cluster																																																									
P	2016	Orlando	Body	Radio																																																									
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																									
P	2016	Orlando	Body	Multimedia Player Interface Module																																																									
P	2016	Orlando	Body	Mobile Telephone Control Module																																																									
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																																									
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
P	2016	Orlando	Body	Front Seat Heating Control Module																																																									
P	2016	Orlando	Body	Rear Seat Heating Control Module																																																									
P	2016	Orlando	Body	Keyless Entry Control Module																																																									
P	2016	Orlando	Body	Parking Assist Control Module																																																									
P	2016	Orlando	Body	Frontview Camera Module																																																									
U	2004	ALL	Powertrain	Engine Control Module					V																																																				
U	2004	ALL	Powertrain	Transmission Control Module																																																									
U	2004	ALL	Body	Digital Radio Receiver																																																									
U	2004	ALL	Body	Driver Information Center																																																									
U	2004	ALL	Body	Instrument Panel Cluster																																																									
U	2004	ALL	Body	Radio																																																									
U	2004	ALL	Body	Supplemental Inflatable Restraint	V																																																								
U	2004	ALL	Body	Vehicle Theft Deterrent																																																									
U	2005	ALL	Powertrain	Engine Control Module					V																																																				
U	2005	ALL	Powertrain	Transmission Control Module																																																									
U	2005	ALL	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
U	2005	ALL	Body	Body Control Module																																	V																							
U	2005	ALL	Body	Disc Player and Video																																																							
U	2005	ALL	Body	Digital Radio Receiver																																																							
U	2005	ALL	Body	HVAC Control Module																												V																												
U	2005	ALL	Body	Instrument Panel Cluster																																																							
U	2005	ALL	Body	Left Power Sliding Door Module																																																							
U	2005	ALL	Body	Mobile Digital Media																																																							
U	2005	ALL	Body	Navigation Radio								V																																															
U	2005	ALL	Body	Navigation Radio								V																																															
U	2005	ALL	Body	Radio								V																																															
U	2005	ALL	Body	Right Power Sliding Door Module																																																							
U	2005	ALL	Body	Supplemental Inflatable Restraint	V																																																							
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module					V																																																			
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																								
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module					V																																																	V	
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																							
U	2006	ALL	Chassis	Electronic Brake Control Module																																																							
U	2006	ALL	Body	Body Control Module																																	V																							
U	2006	ALL	Body	Disc Player and Video																																																							
U	2006	ALL	Body	Digital Radio Receiver																																																							
U	2006	ALL	Body	HVAC Control Module																												V																												
U	2006	ALL	Body	Instrument Panel Cluster																																																							
U	2006	ALL	Body	Left Power Sliding Door Module																																																							
U	2006	ALL	Body	Mobile Digital Media																																																							
U	2006	ALL	Body	Navigation Radio								V																																															
U	2006	ALL	Body	Navigation Radio								V																																															
U	2006	ALL	Body	Radio								V																																															
U	2006	ALL	Body	Right Power Sliding Door Module																																																							
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module					V																																														V			V
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																							
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module					V																																														V			V
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																							
U	2007	ALL	Chassis	Electronic Brake Control Module																																																							
U	2007	ALL	Body	Body Control Module																																	V																							
U	2007	ALL	Body	Digital Radio Receiver																																																							
U	2007	ALL	Body	Disc Player and Video Display																																																							
U	2007	ALL	Body	HVAC Control Module																												V																												
U	2007	ALL	Body	Left Power Sliding Door Module																																																							
U	2007	ALL	Body	Mobile Digital Media																																																							
U	2007	ALL	Body	Radio								V																																															
U	2007	ALL	Body	Navigation Radio								V																																															
U	2007	ALL	Body	Right Power Sliding Door Module																																																							
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module					V																																														V			V
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																							
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module					V																																														V			V
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																							
U	2008	ALL	Chassis	Electronic Brake Control Module																																																							
U	2008	ALL	Body	Body Control Module																																	V																							
U	2008	ALL	Body	Digital Radio Receiver																																																							
U	2008	ALL	Body	Disc Player and Video Display																																																							
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																									
U	2008	ALL	Body	Left Power Sliding Door Module																																																										
U	2008	ALL	Body	Radio								V																																																	
U	2008	ALL	Body	Navigation Radio								V																																																	
U	2008	ALL	Body	Remote Control Door Lock Receiver																																								V		V															
U	2008	ALL	Body	Right Power Sliding Door Module																																																									
U	2009	ALL	Powertrain	Engine Control Module					V																																															V		V	V
U	2009	ALL	Powertrain	Transmission Control Module																																																								
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM											V	V																																												
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																								
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM											V	V																																												
U	2009	ALL	Body	Body Control Module																																V																									
U	2009	ALL	Body	Digital Radio Receiver																																																									
U	2009	ALL	Body	Disc Player and Video Display																																																									
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																																									
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																									
U	2009	ALL	Body	Instrument Panel Cluster																																																									
U	2009	ALL	Body	Left Power Sliding Door Module																																																									
U	2009	ALL	Body	Radio								V																																																	
U	2009	ALL	Body	Remote Control Door Lock Receiver																																								V		V															
U	2009	ALL	Body	Right Power Sliding Door Module																																																									
V	2004	ALL	Powertrain	Engine Data Display					V																																																				
V	2004	ALL	Powertrain	Transmission Data Display																																																									
V	2004	ALL	Body	Digital Radio Receiver																																																									
V	2004	ALL	Body	Driver Information Center																																																									
V	2004	ALL	Body	Instrument Panel Cluster																																																									
V	2004	ALL	Body	Radio																																																									
V	2004	ALL	Body	Supplemental Inflatable Restraint	V																																																									
V	2004	ALL	Body	Vehicle Theft Deterrent																																																									
V	2005	Venture	Powertrain	Engine Control Module					V																																																				
V	2005	Venture	Powertrain	Transmission Control Module																																																									
V	2005	Venture	Body	Digital Radio Receiver																																																									
V	2005	Venture	Body	Driver Information Center																																																									
V	2005	Venture	Body	Instrument Panel Cluster																																																									
V	2005	Venture	Body	Radio																																																									
V	2005	Venture	Body	Supplemental Inflatable Restraint	V																																																									
V	2005	Venture	Body	Vehicle Theft Deterrent																																																									
V	2005	Uplander	Powertrain	Engine Control Module					V																																																				
V	2005	Uplander	Powertrain	Transmission Control Module																																																									
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																									
V	2005	Uplander	Body	Body Control Module																																V																									
V	2005	Uplander	Body	Disc Player and Video																																																									
V	2005	Uplander	Body	Digital Radio Receiver																																																									
V	2005	Uplander	Body	HVAC Control Module																												V																													
V	2005	Uplander	Body	Instrument Panel Cluster																																																									
V	2005	Uplander	Body	Left Power Sliding Door Module																																																									
V	2005	Uplander	Body	Mobile Digital Media																																																									
V	2005	Uplander	Body	Navigation Radio								V																																																	
V	2005	Uplander	Body	Navigation Radio								V																																																	
V	2005	Uplander	Body	Radio								V																																																	
V	2005	Uplander	Body	Right Power Sliding Door Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
V	2005	Uplander	Body	Supplemental Inflatable Restraint	V																																																							
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module					V																																																			
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																								
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module					V																																																	V	
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																							
V	2006	ALL	Chassis	Electronic Brake Control Module																																																							
V	2006	ALL	Body	Body Control Module																																V																							
V	2006	ALL	Body	Disc Player and Video																																																						
V	2006	ALL	Body	Digital Radio Receiver																																																						
V	2006	ALL	Body	HVAC Control Module																												V																										
V	2006	ALL	Body	Instrument Panel Cluster																																																						
V	2006	ALL	Body	Left Power Sliding Door Module																																																						
V	2006	ALL	Body	Mobile Digital Media																																																						
V	2006	ALL	Body	Navigation Radio								V																																														
V	2006	ALL	Body	Navigation Radio								V																																														
V	2006	ALL	Body	Radio								V																																														
V	2006	ALL	Body	Right Power Sliding Door Module																																																						
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module					V																																													V			V
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																						
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module					V																																													V			V
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																						
V	2007	ALL	Chassis	Electronic Brake Control Module																																																						
V	2007	ALL	Body	Body Control Module																																V																						
V	2007	ALL	Body	Digital Radio Receiver																																																						
V	2007	ALL	Body	Disc Player and Video Display																																																						
V	2007	ALL	Body	HVAC Control Module																												V																										
V	2007	ALL	Body	Left Power Sliding Door Module																																																						
V	2007	ALL	Body	Mobile Digital Media																																																						
V	2007	ALL	Body	Radio								V																																														
V	2007	ALL	Body	Navigation Radio								V																																														
V	2007	ALL	Body	Right Power Sliding Door Module																																																						
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module					V																																													V			V
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																						
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module					V																																													V			V
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																						
V	2008	ALL	Chassis	Electronic Brake Control Module																																																						
V	2008	ALL	Body	Body Control Module																																V																						
V	2008	ALL	Body	Digital Radio Receiver																																																						
V	2008	ALL	Body	Disc Player and Video Display																																																						
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																																						
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																						
V	2008	ALL	Body	Left Power Sliding Door Module																																																						
V	2008	ALL	Body	Radio								V																																														
V	2008	ALL	Body	Navigation Radio								V																																														
V	2008	ALL	Body	Remote Control Door Lock Receiver																																								V		V													
V	2008	ALL	Body	Right Power Sliding Door Module																																																						
V	2009	ALL	Powertrain	Engine Control Module					V																																													V		V	V
V	2009	ALL	Powertrain	Transmission Control Module																																																						
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM										V	V																																											
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																						
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM										V	V																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
V	2009	ALL	Body	Body Control Module																																	V																									
V	2009	ALL	Body	Digital Radio Receiver																																																										
V	2009	ALL	Body	Disc Player and Video Display																																																										
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																																										
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																										
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																										
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																										
V	2009	ALL	Body	Left Power Sliding Door Module																																																										
V	2009	ALL	Body	Radio								V																																																	
V	2009	ALL	Body	Remote Control Door Lock Receiver																																								V		V																
V	2009	ALL	Body	Right Power Sliding Door Module																																																										
X	2004	ALL	Powertrain	Engine Control Module					V																																																					
X	2004	ALL	Powertrain	Transmission Control Module																																																										
X	2004	ALL	Body	Digital Radio Receiver																																																										
X	2004	ALL	Body	Driver Information Center																																																										
X	2004	ALL	Body	Instrument Panel Cluster																																																										
X	2004	ALL	Body	Radio																																																										
X	2004	ALL	Body	Supplemental Inflatable Restraint	V																																																									
X	2004	ALL	Body	Vehicle Theft Deterrent																																																										
X	2005	ALL	Powertrain	Engine Control Module					V																																																					
X	2005	ALL	Powertrain	Transmission Control Module																																																										
X	2005	ALL	Chassis	Electronic Brake Control Module																																																										
X	2005	ALL	Body	Body Control Module																																	V																										
X	2005	ALL	Body	Disc Player and Video																																																										
X	2005	ALL	Body	Digital Radio Receiver																																																										
X	2005	ALL	Body	HVAC Control Module																													V																													
X	2005	ALL	Body	Instrument Panel Cluster																																																										
X	2005	ALL	Body	Left Power Sliding Door Module																																																										
X	2005	ALL	Body	Mobile Digital Media																																																										
X	2005	ALL	Body	Navigation Radio								V																																																	
X	2005	ALL	Body	Navigation Radio								V																																																	
X	2005	ALL	Body	Radio								V																																																	
X	2005	ALL	Body	Right Power Sliding Door Module																																																										
X	2005	ALL	Body	Supplemental Inflatable Restraint	V																																																									
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module					V																																																					
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
X	2006	ALL	Chassis	Electronic Brake Control Module																																																										
X	2006	ALL	Body	Body Control Module																																	V																										
X	2006	ALL	Body	Disc Player and Video																																																										
X	2006	ALL	Body	Digital Radio Receiver																																																										
X	2006	ALL	Body	HVAC Control Module																													V																													
X	2006	ALL	Body	Instrument Panel Cluster																																																										
X	2006	ALL	Body	Left Power Sliding Door Module																																																										
X	2006	ALL	Body	Mobile Digital Media																																																										
X	2006	ALL	Body	Navigation Radio								V																																																	
X	2006	ALL	Body	Navigation Radio								V																																																	
X	2006	ALL	Body	Radio								V																																																	
X	2006	ALL	Body	Right Power Sliding Door Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module										V																																																	
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module	V																																																										
A	2006	ALL	Powertrain	Transmission Control Module																																																												
A	2006	ALL	Chassis	Electronic Brake Control Module																																																												
A	2006	ALL	Chassis	Power Steering Control Module																																																												
A	2006	ALL	Body	Body Control Module																					V	V		V			V																																		
A	2006	ALL	Body	Digital Radio Receiver																																																												
A	2006	ALL	Body	Instrument Panel Cluster																																																												
A	2006	ALL	Body	Radio																																																												
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
A	2006	ALL	Body	Theft Deterrent Module																																																												
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module										V																																																			
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																													
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module	V																																																											
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																													
A	2007	ALL	Chassis	Electronic Brake Control Module																																																													
A	2007	ALL	Chassis	Power Steering Control Module																																																													
A	2007	ALL	Body	Body Control Module																					V	V		V			V																																		
A	2007	ALL	Body	Digital Radio Receiver																																																												
A	2007	ALL	Body	Instrument Panel Cluster																																																												
A	2007	ALL	Body	Radio																																																												
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
A	2007	ALL	Body	Theft Deterrent Module																																																												
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module				V						V																																																		
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																													
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module	V									V																																																		
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																													
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module	V																																																											
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																													
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES																																																													
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES																																																													
A	2008	HHR	Chassis	Power Steering Control Module																																																													
A	2008	HHR	Chassis	Power Steering Control Module																																																													
A	2008	HHR	Body	Body Control Module																					V	V		V			V																																		
A	2008	HHR	Body	Digital Radio Receiver																																																												
A	2008	HHR	Body	Instrument Panel Cluster																																																												
A	2008	HHR	Body	Radio																																																												
A	2008	HHR	Body	Supplemental Inflatable Restraint																																																												
A	2008	HHR	Body	Theft Deterrent Module																																																												
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module				V						V																																																		
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																													
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module	V									V																																																		
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																													
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module	V																																																											
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																													
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																													
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																													
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																													
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																													
A	2008	HHR Panel	Body	Body Control Module																					V	V		V			V																																		
A	2008	HHR Panel	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2008	HHR Panel	Body	Radio																																																										
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2008	HHR Panel	Body	Theft Deterrent Module																																																										
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																																										
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module				V					V																																																	
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module	V			V																																																							
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																											
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module	V			V																																																							
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																											
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																																											
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2009	HHR	Chassis	Power Steering Control Module																																																											
A	2009	HHR	Chassis	Power Steering Control Module																																																											
A	2009	HHR	Body	Body Control Module																					V	V		V			V																																	
A	2009	HHR	Body	Digital Radio Receiver																																																											
A	2009	HHR	Body	Instrument Panel Cluster																																																											
A	2009	HHR	Body	Radio																																																											
A	2009	HHR	Body	Supplemental Inflatable Restraint																																																											
A	2009	HHR	Body	Theft Deterrent Module																																																											
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module				V					V																																																		
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																											
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module	V			V																																																							
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																											
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module	V			V																																																							
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																											
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																											
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2009	HHR Panel	Body	Body Control Module																					V	V		V			V																																	
A	2009	HHR Panel	Body	Digital Radio Receiver																																																											
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																											
A	2009	HHR Panel	Body	Radio																																																											
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																																											
A	2009	HHR Panel	Body	Theft Deterrent Module																																																											
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																											
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																											
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module	V			V																																																							
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																											
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module	V			V																																																							
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																											
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																																											
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2010	HHR	Chassis	Power Steering Control Module																																																											
A	2010	HHR	Chassis	Power Steering Control Module																																																											
A	2010	HHR	Body	Body Control Module																					V	V		V			V																																	
A	2010	HHR	Body	Digital Radio Receiver																																																											
A	2010	HHR	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2010	HHR	Body	Radio																																																											
A	2010	HHR	Body	Supplemental Inflatable Restraint																																																											
A	2010	HHR	Body	Theft Deterrent Module																																																											
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																											
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																											
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module	V			V																																																							
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																											
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module	V			V																																																							
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																											
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																											
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2010	HHR Panel	Body	Body Control Module																					V	V		V			V																																
A	2010	HHR Panel	Body	Digital Radio Receiver																																																											
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																											
A	2010	HHR Panel	Body	Radio																																																											
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																																											
A	2010	HHR Panel	Body	Theft Deterrent Module																																																											
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module	V			V																																																							
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																											
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module	V			V																																																							
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																											
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																																											
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2011	HHR	Chassis	Power Steering Control Module																																																											
A	2011	HHR	Body	Body Control Module																					V	V		V			V																																
A	2011	HHR	Body	Digital Radio Receiver																																																											
A	2011	HHR	Body	Instrument Panel Cluster																																																											
A	2011	HHR	Body	Radio																																																											
A	2011	HHR	Body	Supplemental Inflatable Restraint																																																											
A	2011	HHR	Body	Theft Deterrent Module																																																											
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module	V			V																																																							
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																											
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module	V			V																																																							
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																											
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																											
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2011	HHR Panel	Body	Body Control Module																					V	V		V			V																																
A	2011	HHR Panel	Body	Digital Radio Receiver																																																											
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																											
A	2011	HHR Panel	Body	Radio																																																											
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																																											
A	2011	HHR Panel	Body	Theft Deterrent Module																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V			V																																																						
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V			V																																																						
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer	V			V																																																						
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer	V			V																																																						
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
A	2013	Trax	Chassis	Electronic Brake Control Module																																																										
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Trax	Chassis	Power Steering Control Module																																																										
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	Trax	Body	Body Control Module																																																									
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	Trax	Body	Passenger Presence Module																																																										
A	2013	Trax	Body	Instrument Cluster																																																									
A	2013	Trax	Body	Radio																																																									
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
A	2013	Trax	Body	Front Seat Heating Control Module																																																										
A	2013	Trax	Body	Parking Assist Control Module																																																										
A	2013	Trax	Body	Frontview Camera Module																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																											
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V			V																																																						
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V			V																																																						
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																										
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
A	2014	Trax	Chassis	Electronic Brake Control Module																																																										
A	2014	Trax	Chassis	Power Steering Control Module																																																										
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	Trax	Body	Body Control Module																																																										
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	Trax	Body	Passenger Presence Module																																																										
A	2014	Trax	Body	Instrument Cluster																																																										
A	2014	Trax	Body	Radio																																																										
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
A	2014	Trax	Body	Front Seat Heating Control Module																																																										
A	2014	Trax	Body	Parking Assist Control Module																																																										
A	2014	Trax	Body	Frontview Camera Module																																																										
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission	V			V																																																						
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission	V			V																																																						
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																										
A	2015	Trax	Powertrain	Chassis Control Module																																																										
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
A	2015	Trax	Chassis	Electronic Brake Control Module																																																										
A	2015	Trax	Chassis	Power Steering Control Module																																																										
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	Trax	Body	Body Control Module																																																										
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	Trax	Body	Passenger Presence Module																																																										
A	2015	Trax	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2015	Trax	Body	Radio																																																										
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
A	2015	Trax	Body	Seat Memory Control Module																																																										
A	2015	Trax	Body	Front Seat Heating Control Module																																																										
A	2015	Trax	Body	Right Side Object Detection Control Module																																																										
A	2015	Trax	Body	Left Side Object Detection Control Module																																																										
A	2015	Trax	Body	Parking Assist Control Module																																																										
A	2015	Trax	Body	Frontview Camera Module																																																										
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																										
A	2016	Trax	Powertrain	Chassis Control Module																																																										
A	2016	Trax	Chassis	Electronic Brake Control Module																																																										
A	2016	Trax	Chassis	Power Steering Control Module																																																										
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	Trax	Body	Body Control Module																																																										
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	Trax	Body	Passenger Presence Module																																																										
A	2016	Trax	Body	Instrument Cluster																																																										
A	2016	Trax	Body	Trailer Interface Control Module																																																										
A	2016	Trax	Body	Radio																																																										
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
A	2016	Trax	Body	Seat Memory Control Module																																																										
A	2016	Trax	Body	Front Seat Heating Control Module																																																										
A	2016	Trax	Body	Right Side Object Detection Control Module																																																										
A	2016	Trax	Body	Left Side Object Detection Control Module																																																										
A	2016	Trax	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2016	Trax	Body	Frontview Camera Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																									
C	2004	ALL	Body	CD Changer																																																									
C	2004	ALL	Body	Chime																																																									
C	2004	ALL	Body	Driver Door Module																																																									
C	2004	ALL	Body	Driver Seat Module																																																									
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2004	ALL	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2004	ALL	Body	OnStar																																																										
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Radio Base																																																										
C	2004	ALL	Body	Radio Uplevel																																																										
C	2004	ALL	Body	Radio Navigation																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																											
C	2004	ALL	Body	Rear HVAC																																																											
C	2004	ALL	Body	Rear Seat Audio																																																											
C	2004	ALL	Body	Rear Seat Entertainment																																																											
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
C	2004	ALL	Body	Vehicle Theft Deterrent																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																											
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																											
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																											
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
C	2005	ALL	Chassis	ESC																																																										
C	2005	ALL	Chassis	Rear Wheel Steering																																																											
C	2005	ALL	Chassis	Tire Pressure Monitor																																																											
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2005	ALL	Chassis	VSES																																																										
C	2005	ALL	Body	Amplifier (Bose)																																																											
C	2005	ALL	Body	Body Control Module																																																											
C	2005	ALL	Body	CD Changer																																																											
C	2005	ALL	Body	Chime																																																											
C	2005	ALL	Body	Disc Player and Video Display																																																												
C	2005	ALL	Body	Driver Door Module																																																												
C	2005	ALL	Body	Driver Seat Module																																																												
C	2005	ALL	Body	Generator Battery Control Module																																																												
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																												
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																												
C	2005	ALL	Body	Instrument Panel Cluster																																																												
C	2005	ALL	Body	Passenger Door Module																																																												
C	2005	ALL	Body	Passenger Presence System																																																												
C	2005	ALL	Body	Base Radio																																																												
C	2005	ALL	Body	Uplevel Radio																																																												
C	2005	ALL	Body	Navigation Radio																																																												
C	2005	ALL	Body	Rear Aux. Climate Module																																																												
C	2005	ALL	Body	Rear HVAC																																																												
C	2005	ALL	Body	Rear Seat Audio																																																												
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																												
C	2005	ALL	Body	Vehicle Theft Deterrent																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module					V																																																						
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module			V																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module			V																																																							
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed			V																																																						
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																									
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																										
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module				V																																																						
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																						
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																						
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module				V																																																						
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																									
C	2007	Avalanche	Body	Amplifier (Bose)																																																										
C	2007	Avalanche	Body	Assist Step Controller																																																										
C	2007	Avalanche	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
C	2007	Avalanche	Body	Body Control Module (aux.)																																																										
C	2007	Avalanche	Body	Digital Radio Receiver																																																										
C	2007	Avalanche	Body	Driver Door Switch																																																										
C	2007	Avalanche	Body	HVAC Control Module Auto																												V	V																														
C	2007	Avalanche	Body	HVAC Control Module Manual																													V																														
C	2007	Avalanche	Body	Instrument Panel Cluster																																																										
C	2007	Avalanche	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2007	Avalanche	Body	Park Assist Module																																							V	V	V																	
C	2007	Avalanche	Body	Passenger Door Switch																																																										
C	2007	Avalanche	Body	Passenger Presence System																																										V																
C	2007	Avalanche	Body	Radio																																																										
C	2007	Avalanche	Body	Rear Heated Seat Module																																	V				V																					
C	2007	Avalanche	Body	Rear HVAC/RSA																																																										
C	2007	Avalanche	Body	Rollover Sensor																																																										
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																									V									V							
C	2007	Avalanche	Body	Theft Deterrent Module																																																										
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																							
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module				V																																																							
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																							
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module				V																																																							
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module				V																																																							
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2007	Suburban	Chassis	Electronic Suspension Control																																																											
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																											
C	2007	Suburban	Body	Amplifier (Bose)																																																											
C	2007	Suburban	Body	Assist Step Controller																																																											
C	2007	Suburban	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																
C	2007	Suburban	Body	Body Control Module (aux.)																																																											
C	2007	Suburban	Body	Digital Radio Receiver																																																											
C	2007	Suburban	Body	Driver Door Switch																																																											
C	2007	Suburban	Body	HVAC Control Module Auto																												V	V																														
C	2007	Suburban	Body	HVAC Control Module Manual																													V																														
C	2007	Suburban	Body	Instrument Panel Cluster																																																											
C	2007	Suburban	Body	Lift Gate Module																																																											
C	2007	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2007	Suburban	Body	Park Assist Module																																							V	V	V																	
C	2007	Suburban	Body	Passenger Door Switch																																																											
C	2007	Suburban	Body	Passenger Presence System																																										V																
C	2007	Suburban	Body	Radio																																																										
C	2007	Suburban	Body	Rear Heated Seat Module																																	V				V																					

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2007	Suburban	Body	Rear HVAC/RSA																																																									
C	2007	Suburban	Body	Rollover Sensor																																																									
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																									V									V					
C	2007	Suburban	Body	Theft Deterrent Module																																																							
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V																																																				
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module				V																																																				
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																				
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																				
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																				
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module				V																																																				
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																				
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																						
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module				V																																																				
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																				
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2007	Silverado	Chassis	Electronic Suspension Control																																																								
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																								
C	2007	Silverado	Body	Amplifier (Bose)																																																								
C	2007	Silverado	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																														
C	2007	Silverado	Body	Body Control Module (aux.)																																																								
C	2007	Silverado	Body	Digital Radio Receiver																																																								
C	2007	Silverado	Body	Driver Door Switch																																																								
C	2007	Silverado	Body	HVAC Control Module Auto																												V	V																												
C	2007	Silverado	Body	HVAC Control Module Manual																													V																												
C	2007	Silverado	Body	Instrument Panel Cluster																																																								
C	2007	Silverado	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																		
C	2007	Silverado	Body	Park Assist Module																																							V	V	V															
C	2007	Silverado	Body	Passenger Door Switch																																																								
C	2007	Silverado	Body	Passenger Presence System																																									V															
C	2007	Silverado	Body	Radio																																																								
C	2007	Silverado	Body	Rear Heated Seat Module																																	V				V																		
C	2007	Silverado	Body	Rear HVAC/RSA																																																								
C	2007	Silverado	Body	Rollover Sensor																																																								
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																									V									V					
C	2007	Silverado	Body	Theft Deterrent Module																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module				V																																																						
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																						
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																						
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2007	Tahoe	Body	Amplifier (Bose)																																																										
C	2007	Tahoe	Body	Assist Step Controller																																																										
C	2007	Tahoe	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
C	2007	Tahoe	Body	Body Control Module (aux.)																																																										
C	2007	Tahoe	Body	Digital Radio Receiver																																																										
C	2007	Tahoe	Body	Driver Door Switch																																																										
C	2007	Tahoe	Body	HVAC Control Module Auto																												V	V																														
C	2007	Tahoe	Body	HVAC Control Module Manual																													V																														
C	2007	Tahoe	Body	Instrument Panel Cluster																																																										
C	2007	Tahoe	Body	Lift Gate Module																																																										
C	2007	Tahoe	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																				
C	2007	Tahoe	Body	Park Assist Module																																							V	V	V																	
C	2007	Tahoe	Body	Passenger Door Switch																																																										
C	2007	Tahoe	Body	Passenger Presence System																																										V																
C	2007	Tahoe	Body	Radio																																																									
C	2007	Tahoe	Body	Rear Heated Seat Module																																	V				V																				
C	2007	Tahoe	Body	Rear HVAC/RSA																																																										
C	2007	Tahoe	Body	Rollover Sensor																																																										
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																										V									V						
C	2007	Tahoe	Body	Theft Deterrent Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																							
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																							
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2008	Avalanche	Chassis	Electronic Brake Control Module																																																											
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																											
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																											
C	2008	Avalanche	Body	Amplifier (Bose)																																																											
C	2008	Avalanche	Body	Assist Step Controller																																																											
C	2008	Avalanche	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																															
C	2008	Avalanche	Body	Body Control Module (aux.)																																																											
C	2008	Avalanche	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2008	Avalanche	Body	Driver Door Switch																																																										
C	2008	Avalanche	Body	HVAC Control Module Auto																												V	V																													
C	2008	Avalanche	Body	HVAC Control Module Manual																													V																													
C	2008	Avalanche	Body	Instrument Panel Cluster																																																										
C	2008	Avalanche	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2008	Avalanche	Body	Park Assist Module																																							V	V	V																	
C	2008	Avalanche	Body	Passenger Door Switch																																																									
C	2008	Avalanche	Body	Passenger Presence System																																										V																
C	2008	Avalanche	Body	Radio																																																									
C	2008	Avalanche	Body	Rear Heated Seat Module																																	V				V																					
C	2008	Avalanche	Body	Rear HVAC/RSA																																																									
C	2008	Avalanche	Body	Rollover Sensor																																																									
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																										V										V					
C	2008	Avalanche	Body	Theft Deterrent Module																																																									
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																						
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																						
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																								
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																						
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW														V																																											
C	2008	Suburban	Chassis	Electronic Suspension Control																																																										
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																										
C	2008	Suburban	Body	Amplifier (Bose)																																																										
C	2008	Suburban	Body	Assist Step Controller																																																										
C	2008	Suburban	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																															
C	2008	Suburban	Body	Body Control Module (aux.)																																																										
C	2008	Suburban	Body	Digital Radio Receiver																																																										
C	2008	Suburban	Body	Driver Door Switch																																																										
C	2008	Suburban	Body	HVAC Control Module Auto																												V	V																														
C	2008	Suburban	Body	HVAC Control Module Manual																													V																														
C	2008	Suburban	Body	Instrument Panel Cluster																																																										
C	2008	Suburban	Body	Lift Gate Module																																																										
C	2008	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2008	Suburban	Body	Park Assist Module																																							V	V	V																	
C	2008	Suburban	Body	Passenger Door Switch																																																										
C	2008	Suburban	Body	Passenger Presence System																																										V																
C	2008	Suburban	Body	Radio																																																									
C	2008	Suburban	Body	Rear Heated Seat Module																																	V				V																					
C	2008	Suburban	Body	Rear HVAC/RSA																																																										
C	2008	Suburban	Body	Rollover Sensor																																																										
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																										V										V					

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2008	Suburban	Body	Theft Deterrent Module																																																											
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V																																																							
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																								
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																								
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																								
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																								
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																								
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																										
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																								
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																									
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Silverado	Chassis	Electronic Suspension Control																																																												
C	2008	Silverado	Chassis	Trailer Brake Control Module																																																												
C	2008	Silverado	Body	Amplifier (Bose)																																																												
C	2008	Silverado	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																																	
C	2008	Silverado	Body	Body Control Module (aux.)																																																												
C	2008	Silverado	Body	Digital Radio Receiver																																																												
C	2008	Silverado	Body	Driver Door Switch																																																												
C	2008	Silverado	Body	HVAC Control Module Auto																												V	V																															
C	2008	Silverado	Body	HVAC Control Module Manual																													V																															
C	2008	Silverado	Body	Instrument Panel Cluster																																																												
C	2008	Silverado	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																					
C	2008	Silverado	Body	Park Assist Module																																							V	V	V																		
C	2008	Silverado	Body	Passenger Door Switch																																																											
C	2008	Silverado	Body	Passenger Presence System																																									V																	
C	2008	Silverado	Body	Radio																																																											
C	2008	Silverado	Body	Rear Heated Seat Module																																	V			V																					
C	2008	Silverado	Body	Rear HVAC/RSA																																																											
C	2008	Silverado	Body	Rollover Sensor																																																											
C	2008	Silverado	Body	Supplemental Inflatable Restraint																																									V									V						
C	2008	Silverado	Body	Theft Deterrent Module																																																											
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																																											
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																								
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																					
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																					
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
C	2008	Tahoe	Chassis	Electronic Brake Control Module																																																									
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																									
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																									
C	2008	Tahoe	Body	Amplifier (Bose)																																																									
C	2008	Tahoe	Body	Assist Step Controller																																																									
C	2008	Tahoe	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																														
C	2008	Tahoe	Body	Body Control Module (aux.)																																																									
C	2008	Tahoe	Body	Digital Radio Receiver																																																									
C	2008	Tahoe	Body	Driver Door Switch																																																									
C	2008	Tahoe	Body	HVAC Control Module Auto																												V	V																													
C	2008	Tahoe	Body	HVAC Control Module Manual																													V																													
C	2008	Tahoe	Body	Instrument Panel Cluster																																																									
C	2008	Tahoe	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
C	2008	Tahoe	Body	Park Assist Module																																							V	V	V																
C	2008	Tahoe	Body	Passenger Presence System																																										V														
C	2008	Tahoe	Body	Radio																																																								
C	2008	Tahoe	Body	Rear Heated Seat Module																																	V				V																			
C	2008	Tahoe	Body	Rear HVAC/RSA																																																									
C	2008	Tahoe	Body	Rollover Sensor																																																									
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																										V									V					
C	2008	Tahoe	Body	Theft Deterrent Module																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																					
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																		
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																							
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																									
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
C	2008	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																														
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																																									
C	2008	Tahoe Hybrid	Body	HVAC Control Module																												V	V																												
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
C	2008	Tahoe Hybrid	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
C	2008	Tahoe Hybrid	Body	Park Assist Module																																							V	V	V																
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																										V														

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2008	Tahoe Hybrid	Body	Radio																																																												
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																		V				V																						
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																																												
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																										V								V								
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed		V																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																												
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed		V																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed		V																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																								
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module		V																																																										
C	2009	Avalanche	Chassis	Electronic Brake Control Module																																																												
C	2009	Avalanche	Chassis	Electronic Suspension Control																																																												
C	2009	Avalanche	Chassis	Trailer Brake Control Module																																																												
C	2009	Avalanche	Body	Amplifier (Bose)																																																												
C	2009	Avalanche	Body	Assist Step Controller																																																												
C	2009	Avalanche	Body	Body Control Module														V	V	V	V	V		V		V	V			V																																		
C	2009	Avalanche	Body	Body Control Module (aux.)																																																												
C	2009	Avalanche	Body	Digital Radio Receiver																																																												
C	2009	Avalanche	Body	Driver Door Switch																																																												
C	2009	Avalanche	Body	HVAC Control Module Auto																												V	V																															
C	2009	Avalanche	Body	HVAC Control Module Manual																													V																															
C	2009	Avalanche	Body	Instrument Panel Cluster																																																												
C	2009	Avalanche	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																							
C	2009	Avalanche	Body	Park Assist Module																																							V	V	V																			
C	2009	Avalanche	Body	Passenger Door Switch																																																												
C	2009	Avalanche	Body	Passenger Presence System																																										V																		
C	2009	Avalanche	Body	Radio																																																												
C	2009	Avalanche	Body	Rear Heated Seat Module																																		V				V																						
C	2009	Avalanche	Body	Rear HVAC/RSA																																																												
C	2009	Avalanche	Body	Rollover Sensor																																																												
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																																										V								V								
C	2009	Avalanche	Body	Theft Deterrent Module																																																												
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																								
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V			V																																																								
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																												
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																											
C	2009	Cheyenne	Body	Amplifier (Bose)																																																											
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																											
C	2009	Cheyenne	Body	Digital Radio Receiver																																																											
C	2009	Cheyenne	Body	Driver Door Switch																																																											
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																											
C	2009	Cheyenne	Body	Park Assist Module																																							V	V	V																		
C	2009	Cheyenne	Body	Passenger Door Switch																																																											
C	2009	Cheyenne	Body	Passenger Presence System																																										V																	
C	2009	Cheyenne	Body	Rear Heated Seat Module																																	V				V																						
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																											
C	2009	Cheyenne	Body	Rollover Sensor																																																											
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																										V									V						
C	2009	Cheyenne	Body	Theft Deterrent Module																																																											
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																								
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																										
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																								
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																										
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																								
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module		V																																																										
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																								
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																										
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																								
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module		V																																																										
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																								
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																										
C	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																													
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW														V																																														
C	2009	Suburban	Chassis	Electronic Suspension Control																																																													
C	2009	Suburban	Chassis	Trailer Brake Control Module																																																													
C	2009	Suburban	Body	Amplifier (Bose)																																																													
C	2009	Suburban	Body	Assist Step Controller																																																													
C	2009	Suburban	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																	
C	2009	Suburban	Body	Body Control Module (aux.)																																																													
C	2009	Suburban	Body	Digital Radio Receiver																																																													
C	2009	Suburban	Body	Driver Door Switch																																																													
C	2009	Suburban	Body	HVAC Control Module Auto																												V	V																																
C	2009	Suburban	Body	HVAC Control Module Manual																													V																																
C	2009	Suburban	Body	Instrument Panel Cluster																																																													
C	2009	Suburban	Body	Left Side Object Detection Module																																								V							V													
C	2009	Suburban	Body	Lift Gate Module																																																													
C	2009	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																							
C	2009	Suburban	Body	Park Assist Module																																							V	V	V																		

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2009	Suburban	Body	Passenger Door Switch																																																										
C	2009	Suburban	Body	Passenger Presence System																																										V																
C	2009	Suburban	Body	Radio																																																									
C	2009	Suburban	Body	Rear Heated Seat Module																																	V				V																						
C	2009	Suburban	Body	Rear HVAC/RSA																																																										
C	2009	Suburban	Body	Right Side Object Detection Module																																							V					V														
C	2009	Suburban	Body	Rollover Sensor																																																									
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																								V											V						
C	2009	Suburban	Body	Theft Deterrent Module																																																									
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V																																																						
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																						
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																						
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed		V																																																								
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed		V																																																								
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V			V																																																						
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module		V																																																								
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V			V																																																						
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																								
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																							
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module		V																																																									
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																							
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																									
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																								
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES														V																																												
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2009	Silverado	Chassis	Electronic Suspension Control																																																											
C	2009	Silverado	Chassis	Trailer Brake Control Module																																																											
C	2009	Silverado	Body	Amplifier (Bose)																																																											
C	2009	Silverado	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2009	Silverado	Body	Body Control Module (aux.)																																																											
C	2009	Silverado	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2009	Silverado	Body	Driver Door Switch																																																										
C	2009	Silverado	Body	HVAC Control Module Auto																													V	V																												
C	2009	Silverado	Body	HVAC Control Module Manual																														V																												
C	2009	Silverado	Body	Instrument Panel Cluster																																																										
C	2009	Silverado	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																				
C	2009	Silverado	Body	Park Assist Module																																								V	V	V																	
C	2009	Silverado	Body	Passenger Door Switch																																																										
C	2009	Silverado	Body	Passenger Presence System																																											V															
C	2009	Silverado	Body	Radio																																																										
C	2009	Silverado	Body	Rear Heated Seat Module																																	V			V																						
C	2009	Silverado	Body	Rear HVAC/RSA																																																										
C	2009	Silverado	Body	Rollover Sensor																																																										
C	2009	Silverado	Body	Supplemental Inflatable Restraint																																											V									V						
C	2009	Silverado	Body	Theft Deterrent Module																																																										
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																						
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																			
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																								
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2009	Silverado Hybrid	Body	Body Control Module														V	V	V	V	V		V		V	V			V																																
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2009	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2009	Silverado Hybrid	Body	HVAC Control Module																												V	V																													
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2009	Silverado Hybrid	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																				
C	2009	Silverado Hybrid	Body	Park Assist Module																																								V	V	V																	
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2009	Silverado Hybrid	Body	Passenger Presence System																																											V															
C	2009	Silverado Hybrid	Body	Radio																																																										
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																	V			V																						
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2009	Silverado Hybrid	Body	Rollover Sensor																																																										
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																											V									V						
C	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																										
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																						
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																							
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module		V																																																									
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																								
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																										
C	2009	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																																												
C	2009	Tahoe	Body	Amplifier (Bose)																																																												
C	2009	Tahoe	Body	Assist Step Controller																																																												
C	2009	Tahoe	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																	
C	2009	Tahoe	Body	Body Control Module (aux.)																																																												
C	2009	Tahoe	Body	Digital Radio Receiver																																																												
C	2009	Tahoe	Body	Driver Door Switch																																																												
C	2009	Tahoe	Body	HVAC Control Module Auto																												V	V																															
C	2009	Tahoe	Body	HVAC Control Module Manual																													V																															
C	2009	Tahoe	Body	Instrument Panel Cluster																																																											
C	2009	Tahoe	Body	Left Side Object Detection Module																																								V					V													
C	2009	Tahoe	Body	Lift Gate Module																																																											
C	2009	Tahoe	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2009	Tahoe	Body	Park Assist Module																																							V	V	V																	
C	2009	Tahoe	Body	Passenger Door Switch																																																											
C	2009	Tahoe	Body	Passenger Presence System																																										V																
C	2009	Tahoe	Body	Radio																																																										
C	2009	Tahoe	Body	Rear Heated Seat Module																																	V				V																					
C	2009	Tahoe	Body	Rear HVAC/RSA																																																											
C	2009	Tahoe	Body	Right Side Object Detection Module																																								V					V													
C	2009	Tahoe	Body	Rollover Sensor																																																											
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																									V										V					
C	2009	Tahoe	Body	Theft Deterrent Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																							
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																					
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																									
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2009	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																	

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																																											
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																	V				V																						
C	2009	Tahoe Hybrid	Body	HVAC Control Module																												V	V																														
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																							V					V														
C	2009	Tahoe Hybrid	Body	Park Assist Module																																						V	V	V																		
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																											
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																									V																		
C	2009	Tahoe Hybrid	Body	Radio																																																											
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																	V				V																						
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																							V					V														
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																											
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																									V										V						
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																										
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																								
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																										
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Avalanche	Chassis	Electronic Brake Control Module																																																												
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																												
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Avalanche	Body	Amplifier (Bose)																																																												
C	2010	Avalanche	Body	Assist Step Controller																																																												
C	2010	Avalanche	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2010	Avalanche	Body	Body Control Module (aux.)																																																												
C	2010	Avalanche	Body	Digital Radio Receiver																																																												
C	2010	Avalanche	Body	Driver Door Switch																																																												
C	2010	Avalanche	Body	HVAC Control Module Auto																												V	V																															
C	2010	Avalanche	Body	HVAC Control Module Manual																													V																															
C	2010	Avalanche	Body	Instrument Panel Cluster																																																												
C	2010	Avalanche	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2010	Avalanche	Body	Park Assist Module																																						V	V	V																		
C	2010	Avalanche	Body	Passenger Door Switch																																																												
C	2010	Avalanche	Body	Passenger Presence System																																									V																		
C	2010	Avalanche	Body	Radio																																																											
C	2010	Avalanche	Body	Rear Heated Seat Module																																	V				V																						
C	2010	Avalanche	Body	Rear HVAC/RSA																																																												
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																												
C	2010	Avalanche	Body	Theft Deterrent Module																																																												
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																										
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																								
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																											
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																												
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Cheyenne	Body	Amplifier (Bose)																																																											
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																											
C	2010	Cheyenne	Body	Digital Radio Receiver																																																											
C	2010	Cheyenne	Body	Driver Door Switch																																																											
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																											
C	2010	Cheyenne	Body	Park Assist Module																																							V	V	V																		
C	2010	Cheyenne	Body	Passenger Door Switch																																																											
C	2010	Cheyenne	Body	Passenger Presence System																																										V																	
C	2010	Cheyenne	Body	Rear Heated Seat Module																																	V				V																					
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																											
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
C	2010	Cheyenne	Body	Theft Deterrent Module																																																											
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																								
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																										
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																								
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																								
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																										
C	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																												
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW														V																																														
C	2010	Suburban	Chassis	Electronic Suspension Control																																																												
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Suburban	Body	Amplifier (Bose)																																																												
C	2010	Suburban	Body	Assist Step Controller																																																												
C	2010	Suburban	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																	
C	2010	Suburban	Body	Body Control Module (aux.)																																																												
C	2010	Suburban	Body	Digital Radio Receiver																																																												
C	2010	Suburban	Body	Driver Door Switch																																																												
C	2010	Suburban	Body	HVAC Control Module Auto																												V	V																															
C	2010	Suburban	Body	HVAC Control Module Manual																													V																															
C	2010	Suburban	Body	Instrument Panel Cluster																																																												
C	2010	Suburban	Body	Left Side Object Detection Module																																								V					V													
C	2010	Suburban	Body	Lift Gate Module																																																												
C	2010	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2010	Suburban	Body	Park Assist Module																																							V	V	V																	
C	2010	Suburban	Body	Passenger Door Switch																																																												
C	2010	Suburban	Body	Passenger Presence System																																									V																	
C	2010	Suburban	Body	Radio																																																											
C	2010	Suburban	Body	Rear Heated Seat Module																																	V				V																					
C	2010	Suburban	Body	Rear HVAC/RSA																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2010	Suburban	Body	Right Side Object Detection Module																																								V						V												
C	2010	Suburban	Body	Supplemental Inflatable Restraint																																																									
C	2010	Suburban	Body	Theft Deterrent Module																																																									
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V			V																																																					
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V			V																																																					
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																					
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																					
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																							
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																					
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																							
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																					
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																							
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic	V			V																																																					
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V			V																																																					
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																							
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																					
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																							
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																						
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES														V																																										
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
C	2010	Silverado	Chassis	Electronic Suspension Control																																																									
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
C	2010	Silverado	Body	Amplifier (Bose)																																																									
C	2010	Silverado	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
C	2010	Silverado	Body	Body Control Module (aux.)																																																									
C	2010	Silverado	Body	Digital Radio Receiver																																																									
C	2010	Silverado	Body	Driver Door Switch																																																									
C	2010	Silverado	Body	HVAC Control Module Auto																												V	V																													
C	2010	Silverado	Body	HVAC Control Module Manual																													V																													
C	2010	Silverado	Body	Instrument Panel Cluster																																																									
C	2010	Silverado	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
C	2010	Silverado	Body	Park Assist Module																																							V	V	V																
C	2010	Silverado	Body	Passenger Door Switch																																																									
C	2010	Silverado	Body	Passenger Presence System																																									V																
C	2010	Silverado	Body	Radio																																																									
C	2010	Silverado	Body	Rear Heated Seat Module																																	V				V																				
C	2010	Silverado	Body	Rear HVAC/RSA																																																									
C	2010	Silverado	Body	Supplemental Inflatable Restraint																																																									
C	2010	Silverado	Body	Theft Deterrent Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																							
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																				
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																									
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																												
C	2010	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																	
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																												
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																												
C	2010	Silverado Hybrid	Body	Heated Seat Module																																	V				V																							
C	2010	Silverado Hybrid	Body	HVAC Control Module																												V	V																															
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
C	2010	Silverado Hybrid	Body	Park Assist Module																																							V	V	V																			
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2010	Silverado Hybrid	Body	Passenger Presence System																																									V																			
C	2010	Silverado Hybrid	Body	Radio																																																											
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																	V				V																							
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Tahoe	Body	Amplifier (Bose)																																																												
C	2010	Tahoe	Body	Assist Step Controller																																																												
C	2010	Tahoe	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																	
C	2010	Tahoe	Body	Body Control Module (aux.)																																																												
C	2010	Tahoe	Body	Digital Radio Receiver																																																												
C	2010	Tahoe	Body	Driver Door Switch																																																												
C	2010	Tahoe	Body	HVAC Control Module Auto																												V	V																															
C	2010	Tahoe	Body	HVAC Control Module Manual																													V																															
C	2010	Tahoe	Body	Instrument Panel Cluster																																																												
C	2010	Tahoe	Body	Left Side Object Detection Module																																								V					V													
C	2010	Tahoe	Body	Lift Gate Module																																																												
C	2010	Tahoe	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2010	Tahoe	Body	Park Assist Module																																							V	V	V																
C	2010	Tahoe	Body	Passenger Door Switch																																																									
C	2010	Tahoe	Body	Passenger Presence System																																										V																
C	2010	Tahoe	Body	Radio																																																								
C	2010	Tahoe	Body	Rear Heated Seat Module																																	V				V																					
C	2010	Tahoe	Body	Rear HVAC/RSA																																																									
C	2010	Tahoe	Body	Right Side Object Detection Module																																							V					V													
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																									
C	2010	Tahoe	Body	Theft Deterrent Module																																																									
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																					
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																			
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																							
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
C	2010	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																																									
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																	V				V																					
C	2010	Tahoe Hybrid	Body	HVAC Control Module																												V	V																													
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																							V					V													
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																																									
C	2010	Tahoe Hybrid	Body	Park Assist Module																																							V	V	V																	
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																									
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																										V																
C	2010	Tahoe Hybrid	Body	Radio																																																									
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																	V				V																					
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																							V					V													
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																									
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																									
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																					
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																							
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																					
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																							
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2011	Avalanche	Chassis	Electronic Brake Control Module																																																									
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																									
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2011	Avalanche	Body	Amplifier (Bose)																																																										
C	2011	Avalanche	Body	Assist Step Controller																																																										
C	2011	Avalanche	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2011	Avalanche	Body	Body Control Module (aux.)																																																										
C	2011	Avalanche	Body	Digital Radio Receiver																																																										
C	2011	Avalanche	Body	Driver Door Switch																																																										
C	2011	Avalanche	Body	HVAC Control Module Auto																												V	V																														
C	2011	Avalanche	Body	HVAC Control Module Manual																													V																														
C	2011	Avalanche	Body	Instrument Panel Cluster																																																										
C	2011	Avalanche	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																					
C	2011	Avalanche	Body	Park Assist Module																																							V	V	V																	
C	2011	Avalanche	Body	Passenger Door Switch																																																										
C	2011	Avalanche	Body	Passenger Presence System																																										V																
C	2011	Avalanche	Body	Radio																																																										
C	2011	Avalanche	Body	Rear Heated Seat Module																																	V				V																					
C	2011	Avalanche	Body	Rear HVAC/RSA																																																										
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2011	Avalanche	Body	Theft Deterrent Module																																																										
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2011	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2011	Captiva	Chassis	Parking Brake Control Module																																																										
C	2011	Captiva	Body	Body Control Module																																																										
C	2011	Captiva	Body	Auxiliary Body Control Module																																																										
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2011	Captiva	Body	Instrument Cluster																																																										
C	2011	Captiva	Body	Headlamp Control Module																																																										
C	2011	Captiva	Body	HVAC Control Module																																																										
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																										
C	2011	Captiva	Body	Parking Assist Control Module																																																										
C	2011	Captiva	Body	Theft Deterrent Module																																																										
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																											
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																										
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Cheyenne	Body	Amplifier (Bose)																																																										
C	2011	Cheyenne	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2011	Cheyenne	Body	Digital Radio Receiver																																																										
C	2011	Cheyenne	Body	Driver Door Switch																																																										
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2011	Cheyenne	Body	Park Assist Module																																							V	V	V																	
C	2011	Cheyenne	Body	Passenger Door Switch																																																										
C	2011	Cheyenne	Body	Passenger Presence System																																										V																
C	2011	Cheyenne	Body	Rear Heated Seat Module																																	V				V																				
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2011	Cheyenne	Body	Theft Deterrent Module																																																										
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW														V																																												
C	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																											
C	2011	Suburban	Chassis	Electronic Suspension Control																																																										
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Suburban	Body	Amplifier (Bose)																																																										
C	2011	Suburban	Body	Assist Step Controller																																																										
C	2011	Suburban	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2011	Suburban	Body	Body Control Module (aux.)																																																										
C	2011	Suburban	Body	Digital Radio Receiver																																																										
C	2011	Suburban	Body	Driver Door Switch																																																										
C	2011	Suburban	Body	HVAC Control Module Auto																												V	V																														
C	2011	Suburban	Body	HVAC Control Module Manual																													V																														
C	2011	Suburban	Body	Instrument Panel Cluster																																																										
C	2011	Suburban	Body	Left Side Object Detection Module																																								V					V													
C	2011	Suburban	Body	Lift Gate Module																																																										
C	2011	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
C	2011	Suburban	Body	Park Assist Module																																							V	V	V																	
C	2011	Suburban	Body	Passenger Door Switch																																																										
C	2011	Suburban	Body	Passenger Presence System																																										V																
C	2011	Suburban	Body	Radio																																																										
C	2011	Suburban	Body	Rear Heated Seat Module																																	V				V																				
C	2011	Suburban	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2011	Suburban	Body	Right Side Object Detection Module																																								V					V													
C	2011	Suburban	Body	Supplemental Inflatable Restraint																																																									
C	2011	Suburban	Body	Theft Deterrent Module																																																									
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V			V																																																						
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V			V																																																						
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic	V			V																																																						
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual	V			V																																																						
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																						
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module			V																																																							
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module			V																																																							
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES														V																																												
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2011	Silverado	Chassis	Electronic Suspension Control																																																										
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2011	Silverado	Body	Amplifier (Bose)																																																										
C	2011	Silverado	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2011	Silverado	Body	Body Control Module (aux.)																																																										
C	2011	Silverado	Body	Digital Radio Receiver																																																										
C	2011	Silverado	Body	Driver Door Switch																																																										
C	2011	Silverado	Body	HVAC Control Module Auto																												V	V																														
C	2011	Silverado	Body	HVAC Control Module Manual																													V																														
C	2011	Silverado	Body	Instrument Panel Cluster																																																										
C	2011	Silverado	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																				
C	2011	Silverado	Body	Park Assist Module																																							V	V	V																	
C	2011	Silverado	Body	Passenger Door Switch																																																										
C	2011	Silverado	Body	Passenger Presence System																																									V																	
C	2011	Silverado	Body	Radio																																																									
C	2011	Silverado	Body	Rear Heated Seat Module																																	V				V																				
C	2011	Silverado	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2011	Silverado	Body	Theft Deterrent Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																						
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																			
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																								
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Silverado Hybrid	Body	Body Control Module														V	V	V	V	V		V		V	V			V																																
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2011	Silverado Hybrid	Body	Heated Seat Module																																V				V																						
C	2011	Silverado Hybrid	Body	HVAC Control Module																												V	V																													
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Silverado Hybrid	Body	Park Assist Module																																							V	V	V																	
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2011	Silverado Hybrid	Body	Passenger Presence System																																										V																
C	2011	Silverado Hybrid	Body	Radio																																																										
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																V				V																						
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe	Body	Amplifier (Bose)																																																										
C	2011	Tahoe	Body	Assist Step Controller																																																										
C	2011	Tahoe	Body	Body Control Module														V	V	V	V	V		V		V	V			V																																
C	2011	Tahoe	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe	Body	Digital Radio Receiver																																																										
C	2011	Tahoe	Body	Driver Door Switch																																																										
C	2011	Tahoe	Body	HVAC Control Module Auto																												V	V																													
C	2011	Tahoe	Body	HVAC Control Module Manual																													V																													
C	2011	Tahoe	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe	Body	Left Side Object Detection Module																																								V					V													
C	2011	Tahoe	Body	Lift Gate Module																																																										
C	2011	Tahoe	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2011	Tahoe	Body	Park Assist Module																																							V	V	V																	

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2011	Tahoe	Body	Passenger Door Switch																																																										
C	2011	Tahoe	Body	Passenger Presence System																																										V																
C	2011	Tahoe	Body	Radio																																																									
C	2011	Tahoe	Body	Rear Heated Seat Module																																	V				V																					
C	2011	Tahoe	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe	Body	Right Side Object Detection Module																																							V				V														
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																									
C	2011	Tahoe	Body	Theft Deterrent Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																						
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																				
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																								
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																	V				V																					
C	2011	Tahoe Hybrid	Body	HVAC Control Module																											V	V																															
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																							V				V														
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2011	Tahoe Hybrid	Body	Park Assist Module																																						V	V	V																		
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																									V																	
C	2011	Tahoe Hybrid	Body	Radio																																																										
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																	V				V																					
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																							V				V														
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																							
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																									
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Avalanche	Chassis	Electronic Brake Control Module														V																																												
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																											
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2012	Avalanche	Body	Amplifier (Bose)																																																										
C	2012	Avalanche	Body	Assist Step Controller																																																										
C	2012	Avalanche	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2012	Avalanche	Body	Body Control Module (aux.)																																																										
C	2012	Avalanche	Body	Digital Radio Receiver																																																										
C	2012	Avalanche	Body	Driver Door Switch																																																										
C	2012	Avalanche	Body	HVAC Control Module Auto																												V	V																														
C	2012	Avalanche	Body	HVAC Control Module Manual																													V																														
C	2012	Avalanche	Body	Instrument Panel Cluster																																																										
C	2012	Avalanche	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																				
C	2012	Avalanche	Body	Navigation Radio																																																										
C	2012	Avalanche	Body	Park Assist Module																																							V	V	V																	
C	2012	Avalanche	Body	Passenger Door Switch																																																										
C	2012	Avalanche	Body	Passenger Presence System																																										V																
C	2012	Avalanche	Body	Radio																																																										
C	2012	Avalanche	Body	Rear Heated Seat Module																																	V				V																					
C	2012	Avalanche	Body	Rear HVAC/RSA																																																										
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2012	Avalanche	Body	Theft Deterrent Module																																																										
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2012	Captiva	Chassis	Parking Brake Control Module																																																										
C	2012	Captiva	Body	Body Control Module																																																										
C	2012	Captiva	Body	Auxiliary Body Control Module																																																										
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2012	Captiva	Body	Instrument Cluster																																																										
C	2012	Captiva	Body	Headlamp Control Module																																																										
C	2012	Captiva	Body	HVAC Control Module																																																										
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																										
C	2012	Captiva	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2012	Captiva	Body	Theft Deterrent Module																																																											
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V			V																																																							
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V			V																																																							
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																							
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																									
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																										
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES														V																																													
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES														V																																													
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																													
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																												
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
C	2012	Cheyenne	Body	Amplifier (Bose)																																																												
C	2012	Cheyenne	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																												
C	2012	Cheyenne	Body	Digital Radio Receiver																																																												
C	2012	Cheyenne	Body	Driver Door Switch																																																												
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																												
C	2012	Cheyenne	Body	Park Assist Module																																							V	V	V																			
C	2012	Cheyenne	Body	Passenger Door Switch																																																												
C	2012	Cheyenne	Body	Passenger Presence System																																										V																	
C	2012	Cheyenne	Body	Rear Heated Seat Module																																	V				V																					
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																												
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																												
C	2012	Cheyenne	Body	Theft Deterrent Module																																																												
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																								
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																										
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																										
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed	V			V																																																								
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																										
C	2012	Suburban	Chassis	EBCM Under 8600 GVW														V																																													
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW														V																																														
C	2012	Suburban	Chassis	Electronic Suspension Control																																																												
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
C	2012	Suburban	Body	Amplifier (Bose)																																																												
C	2012	Suburban	Body	Assist Step Controller																																																												
C	2012	Suburban	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2012	Suburban	Body	Body Control Module (aux.)																																																												
C	2012	Suburban	Body	Digital Radio Receiver																																																												
C	2012	Suburban	Body	Driver Door Switch																																																												
C	2012	Suburban	Body	HVAC Control Module Auto																												V	V																															
C	2012	Suburban	Body	HVAC Control Module Manual																													V																															
C	2012	Suburban	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2012	Suburban	Body	Left Side Object Detection Module																																								V						V											
C	2012	Suburban	Body	Lift Gate Module																																																								
C	2012	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
C	2012	Suburban	Body	Navigation Radio																																																								
C	2012	Suburban	Body	Park Assist Module																																						V	V	V																	
C	2012	Suburban	Body	Passenger Door Switch																																																								
C	2012	Suburban	Body	Passenger Presence System																																									V															
C	2012	Suburban	Body	Radio																																																								
C	2012	Suburban	Body	Rear Heated Seat Module																																	V				V																				
C	2012	Suburban	Body	Rear HVAC/RSA																																																								
C	2012	Suburban	Body	Right Side Object Detection Module																																								V						V											
C	2012	Suburban	Body	Supplemental Inflatable Restraint																																																								
C	2012	Suburban	Body	Theft Deterrent Module																																																								
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V			V																																																					
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V			V																																																					
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																					
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																					
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																							
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																					
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																							
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic	V			V																																																					
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual	V			V																																																					
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																							
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																					
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																							
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																									
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																									
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																									
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module			V																																																						
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																									
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module			V																																																						
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES														V																																											
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES														V																																											
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES														V																																											
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
C	2012	Silverado	Chassis	Electronic Suspension Control																																																									
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
C	2012	Silverado	Body	Amplifier (Bose)																																																									
C	2012	Silverado	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
C	2012	Silverado	Body	Body Control Module (aux.)																																																									
C	2012	Silverado	Body	Digital Radio Receiver																																																									
C	2012	Silverado	Body	Driver Door Switch																																																									
C	2012	Silverado	Body	HVAC Control Module Auto																												V	V																													

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2012	Silverado	Body	HVAC Control Module Manual																												V																												
C	2012	Silverado	Body	Instrument Panel Cluster																																																								
C	2012	Silverado	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																			
C	2012	Silverado	Body	Navigation Radio																																																							
C	2012	Silverado	Body	Park Assist Module																																						V	V	V															
C	2012	Silverado	Body	Passenger Door Switch																																																							
C	2012	Silverado	Body	Passenger Presence System																																									V														
C	2012	Silverado	Body	Radio																																																							
C	2012	Silverado	Body	Rear Heated Seat Module																																	V				V																			
C	2012	Silverado	Body	Rear HVAC/RSA																																																							
C	2012	Silverado	Body	Supplemental Inflatable Restraint																																																							
C	2012	Silverado	Body	Theft Deterrent Module																																																							
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																				
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																		
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																						
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																								
C	2012	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																													
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																								
C	2012	Silverado Hybrid	Body	Driver Door Switch																																																								
C	2012	Silverado Hybrid	Body	Heated Seat Module																																	V				V																			
C	2012	Silverado Hybrid	Body	HVAC Control Module																												V	V																												
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
C	2012	Silverado Hybrid	Body	Navigation Radio																																																								
C	2012	Silverado Hybrid	Body	Park Assist Module																																						V	V	V															
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																																								
C	2012	Silverado Hybrid	Body	Passenger Presence System																																									V															
C	2012	Silverado Hybrid	Body	Radio																																																								
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																	V				V																			
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																								
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																				
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																						
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2012	Tahoe	Chassis	Electronic Brake Control Module														V																																									
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																								
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
C	2012	Tahoe	Body	Amplifier (Bose)																																																								
C	2012	Tahoe	Body	Assist Step Controller																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2012	Tahoe	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
C	2012	Tahoe	Body	Body Control Module (aux.)																																																										
C	2012	Tahoe	Body	Digital Radio Receiver																																																										
C	2012	Tahoe	Body	Driver Door Switch																																																										
C	2012	Tahoe	Body	HVAC Control Module Auto																												V	V																														
C	2012	Tahoe	Body	HVAC Control Module Manual																													V																														
C	2012	Tahoe	Body	Instrument Panel Cluster																																																										
C	2012	Tahoe	Body	Left Side Object Detection Module																																								V					V													
C	2012	Tahoe	Body	Lift Gate Module																																																										
C	2012	Tahoe	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2012	Tahoe	Body	Navigation Radio																																																										
C	2012	Tahoe	Body	Park Assist Module																																						V	V	V																		
C	2012	Tahoe	Body	Passenger Door Switch																																																										
C	2012	Tahoe	Body	Passenger Presence System																																									V																	
C	2012	Tahoe	Body	Radio																																																										
C	2012	Tahoe	Body	Rear Heated Seat Module																																	V				V																					
C	2012	Tahoe	Body	Rear HVAC/RSA																																																										
C	2012	Tahoe	Body	Right Side Object Detection Module																																								V					V													
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2012	Tahoe	Body	Theft Deterrent Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																						
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																						V																																				
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																								
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2012	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																	V				V																					
C	2012	Tahoe Hybrid	Body	HVAC Control Module																												V	V																														
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																								V					V													
C	2012	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2012	Tahoe Hybrid	Body	Navigation Radio																																																											
C	2012	Tahoe Hybrid	Body	Park Assist Module																																						V	V	V																		
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																									V																	
C	2012	Tahoe Hybrid	Body	Radio																																																										
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																	V				V																					
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																								V					V													

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																								
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Avalanche	Chassis	Electronic Brake Control Module														V																																												
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Avalanche	Body	Amplifier (Bose)																																																										
C	2013	Avalanche	Body	Assist Step Controller																																																										
C	2013	Avalanche	Body	Body Control Module														V	V	V	V	V		V		V	V			V																																
C	2013	Avalanche	Body	Body Control Module (aux.)																																																										
C	2013	Avalanche	Body	Digital Radio Receiver																																																										
C	2013	Avalanche	Body	Driver Door Switch																																																										
C	2013	Avalanche	Body	HVAC Control Module Auto																												V	V																													
C	2013	Avalanche	Body	HVAC Control Module Manual																													V																													
C	2013	Avalanche	Body	Instrument Panel Cluster																																																										
C	2013	Avalanche	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																				
C	2013	Avalanche	Body	Navigation Radio																																																										
C	2013	Avalanche	Body	Park Assist Module																																							V	V	V																	
C	2013	Avalanche	Body	Passenger Door Switch																																																										
C	2013	Avalanche	Body	Passenger Presence System																																										V																
C	2013	Avalanche	Body	Radio																																																										
C	2013	Avalanche	Body	Rear Heated Seat Module																																	V				V																					
C	2013	Avalanche	Body	Rear HVAC/RSA																																																										
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2013	Avalanche	Body	Theft Deterrent Module																																																										
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2013	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2013	Captiva	Chassis	Parking Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																										
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																										
C	2013	Captiva	Body	Auxiliary Body Control Module																																																										
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2013	Captiva	Body	Instrument Cluster																																																										
C	2013	Captiva	Body	Headlamp Control Module																																																										
C	2013	Captiva	Body	HVAC Control Module																																																										
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
C	2013	Captiva	Body	Theft Deterrent Module																																																										
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V			V																																																						
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V			V																																																						
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																								
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES														V																																											
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES														V																																											
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																											
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																										
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Cheyenne	Body	Amplifier (Bose)																																																										
C	2013	Cheyenne	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2013	Cheyenne	Body	Digital Radio Receiver																																																										
C	2013	Cheyenne	Body	Driver Door Switch																																																										
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2013	Cheyenne	Body	Park Assist Module																																							V	V	V																		
C	2013	Cheyenne	Body	Passenger Door Switch																																																										
C	2013	Cheyenne	Body	Passenger Presence System																																										V																
C	2013	Cheyenne	Body	Rear Heated Seat Module																																	V				V																					
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2013	Cheyenne	Body	Theft Deterrent Module																																																										
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																								
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed	V			V																																																						
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
C	2013	Suburban	Chassis	EBCM Under 8600 GVW														V																																											
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW														V																																											
C	2013	Suburban	Chassis	Electronic Suspension Control																																																										
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Suburban	Body	Amplifier (Bose)																																																											
C	2013	Suburban	Body	Assist Step Controller																																																										
C	2013	Suburban	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2013	Suburban	Body	Body Control Module (aux.)																																																											
C	2013	Suburban	Body	Digital Radio Receiver																																																											
C	2013	Suburban	Body	Driver Door Switch																																																											
C	2013	Suburban	Body	HVAC Control Module Auto																												V	V																															
C	2013	Suburban	Body	HVAC Control Module Manual																													V																															
C	2013	Suburban	Body	Instrument Panel Cluster																																																											
C	2013	Suburban	Body	Left Side Object Detection Module																																								V					V													
C	2013	Suburban	Body	Lift Gate Module																																																											
C	2013	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																						
C	2013	Suburban	Body	Navigation Radio																																																											
C	2013	Suburban	Body	Park Assist Module																																						V	V	V																			
C	2013	Suburban	Body	Passenger Door Switch																																																											
C	2013	Suburban	Body	Passenger Presence System																																									V																		
C	2013	Suburban	Body	Radio																																																											
C	2013	Suburban	Body	Rear Heated Seat Module																																	V			V																								
C	2013	Suburban	Body	Rear HVAC/RSA																																																											
C	2013	Suburban	Body	Right Side Object Detection Module																																								V					V													
C	2013	Suburban	Body	Supplemental Inflatable Restraint																																																											
C	2013	Suburban	Body	Theft Deterrent Module																																																											
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V			V																																																							
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V			V																																																							
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																							
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																										
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																										
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic	V			V																																																								
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual	V			V																																																								
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																										
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																								
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																													
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																										
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																								
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																										
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module			V																																																									
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES														V																																														
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES														V																																														
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES														V																																														

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2013	Silverado	Chassis	Electronic Suspension Control																																																											
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2013	Silverado	Body	Amplifier (Bose)																																																											
C	2013	Silverado	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2013	Silverado	Body	Body Control Module (aux.)																																																											
C	2013	Silverado	Body	Digital Radio Receiver																																																											
C	2013	Silverado	Body	Driver Door Switch																																																											
C	2013	Silverado	Body	HVAC Control Module Auto																												V	V																															
C	2013	Silverado	Body	HVAC Control Module Manual																													V																															
C	2013	Silverado	Body	Instrument Panel Cluster																																																											
C	2013	Silverado	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																						
C	2013	Silverado	Body	Navigation Radio																																																											
C	2013	Silverado	Body	Park Assist Module																																							V	V	V																			
C	2013	Silverado	Body	Passenger Door Switch																																																											
C	2013	Silverado	Body	Passenger Presence System																																										V																	
C	2013	Silverado	Body	Radio																																																											
C	2013	Silverado	Body	Rear Heated Seat Module																																	V				V																						
C	2013	Silverado	Body	Rear HVAC/RSA																																																											
C	2013	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2013	Silverado	Body	Theft Deterrent Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																							
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																					
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																									
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																											
C	2013	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																											
C	2013	Silverado Hybrid	Body	Driver Door Switch																																																											
C	2013	Silverado Hybrid	Body	Heated Seat Module																																	V				V																						
C	2013	Silverado Hybrid	Body	HVAC Control Module																												V	V																															
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
C	2013	Silverado Hybrid	Body	Navigation Radio																																																												
C	2013	Silverado Hybrid	Body	Park Assist Module																																							V	V	V																			
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2013	Silverado Hybrid	Body	Passenger Presence System																																										V																	
C	2013	Silverado Hybrid	Body	Radio																																																												
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																	V				V																						
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2013	Tahoe	Chassis	Electronic Brake Control Module														V																																												
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe	Body	Amplifier (Bose)																																																											
C	2013	Tahoe	Body	Assist Step Controller																																																											
C	2013	Tahoe	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2013	Tahoe	Body	Body Control Module (aux.)																																																											
C	2013	Tahoe	Body	Digital Radio Receiver																																																											
C	2013	Tahoe	Body	Driver Door Switch																																																											
C	2013	Tahoe	Body	HVAC Control Module Auto																												V	V																															
C	2013	Tahoe	Body	HVAC Control Module Manual																													V																															
C	2013	Tahoe	Body	Instrument Panel Cluster																																																											
C	2013	Tahoe	Body	Left Side Object Detection Module																																								V						V													
C	2013	Tahoe	Body	Lift Gate Module																																																											
C	2013	Tahoe	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																						
C	2013	Tahoe	Body	Navigation Radio																																																											
C	2013	Tahoe	Body	Park Assist Module																																						V	V	V																			
C	2013	Tahoe	Body	Passenger Door Switch																																																											
C	2013	Tahoe	Body	Passenger Presence System																																									V																		
C	2013	Tahoe	Body	Radio																																																										
C	2013	Tahoe	Body	Rear Heated Seat Module																																	V				V																						
C	2013	Tahoe	Body	Rear HVAC/RSA																																																											
C	2013	Tahoe	Body	Right Side Object Detection Module																																								V						V													
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																											
C	2013	Tahoe	Body	Theft Deterrent Module																																																												
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																					
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																									
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2013	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																	V				V																				
C	2013	Tahoe Hybrid	Body	HVAC Control Module																											V	V																												
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																							V				V													
C	2013	Tahoe Hybrid	Body	Lift Gate Module																																																								
C	2013	Tahoe Hybrid	Body	Navigation Radio																																																								
C	2013	Tahoe Hybrid	Body	Park Assist Module																																						V	V	V																
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																								
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																									V															
C	2013	Tahoe Hybrid	Body	Radio																																																								
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																	V				V																				
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																							V				V													
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																								
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																								
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																								
C	2014	Captiva (3GN)	Body	Body Control Module																																																								
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Captiva (3GN)	Body	Passenger Presence Module																																																								
C	2014	Captiva (3GN)	Body	Instrument Cluster																																																								
C	2014	Captiva (3GN)	Body	Radio																																																								
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																								
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																								
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																								
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2014	Captiva (3GN)	Body	HVAC Control Module																																																								
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																								
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																								
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																								
C	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																								
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																								
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																								
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																											
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																											
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																											
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Captiva (Other)	Body	Instrument Cluster																																																											
C	2014	Captiva (Other)	Body	Headlamp Control Module																																																											
C	2014	Captiva (Other)	Body	HVAC Control Module																																																											
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
C	2014	Captiva (Other)	Body	Theft Deterrent Module																																																											
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																											
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																											
C	2014	Cheyenne	Chassis	Power Steering Control Module																																																											
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2014	Cheyenne	Body	Body Control Module																																																											
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Cheyenne	Body	Passenger Presence Module																																																											
C	2014	Cheyenne	Body	Instrument Cluster																																																											
C	2014	Cheyenne	Body	Radio Control																																																											
C	2014	Cheyenne	Body	HVAC Control																																																											
C	2014	Cheyenne	Body	Radio																																																											
C	2014	Cheyenne	Body	Amplifier																																																											
C	2014	Cheyenne	Body	Media Disc Player																																																											
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																											
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																											
C	2014	Cheyenne	Body	HVAC Control Module																																																											
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																											
C	2014	Cheyenne	Body	Parking Assist Control Module																																																											
C	2014	Cheyenne	Body	Frontview Camera Module																																																											
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado	Chassis	Parking Brake Control Module																																																										
C	2014	Silverado	Chassis	Power Steering Control Module																																																										
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Silverado	Body	Body Control Module																																																										
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado	Body	Passenger Presence Module																																																										
C	2014	Silverado	Body	Instrument Cluster																																																										
C	2014	Silverado	Body	Radio Control																																																										
C	2014	Silverado	Body	HVAC Control																																																										
C	2014	Silverado	Body	Radio																																																										
C	2014	Silverado	Body	Amplifier																																																										
C	2014	Silverado	Body	Media Disc Player																																																										
C	2014	Silverado	Body	Human Machine Interface Control Module																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2014	Silverado	Body	Parking Assist Control Module																																																										
C	2014	Silverado	Body	Frontview Camera Module																																																										
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																										
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Suspension Control Module																																																										
C	2014	Silverado HD	Body	Body Control Module																																																										
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado HD	Body	Passenger Presence Module																																																										
C	2014	Silverado HD	Body	Instrument Cluster																																																										
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
C	2014	Silverado HD	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2014	Silverado HD	Body	Navigation Radio																																																												
C	2014	Silverado HD	Body	Uplevel Radio																																																												
C	2014	Silverado HD	Body	Amplifier																																																												
C	2014	Silverado HD	Body	Rear Audio Control Module																																																												
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																												
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																												
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																												
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																												
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																												
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																												
C	2014	Silverado HD	Body	Seat Memory Control Module																																																												
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																												
C	2014	Silverado HD	Body	Parking Assist Control Module																																																												
C	2014	Silverado HD	Body	Theft Deterrent Module																																																												
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																												
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																												
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																												
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																												
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																												
C	2014	Suburban	Chassis	Parking Brake Control Module																																																												
C	2014	Suburban	Chassis	Suspension Control Module																																																												
C	2014	Suburban	Body	Body Control Module																																																												
C	2014	Suburban	Body	Auxiliary Body Control Module																																																												
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Suburban	Body	Passenger Presence Module																																																												
C	2014	Suburban	Body	Instrument Cluster																																																												
C	2014	Suburban	Body	Base Radio																																																												
C	2014	Suburban	Body	Navigation Radio																																																												
C	2014	Suburban	Body	Uplevel Radio																																																												
C	2014	Suburban	Body	Amplifier																																																												
C	2014	Suburban	Body	Rear Audio Control Module																																																												
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																												
C	2014	Suburban	Body	Personal Audio Link Control Module																																																												
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																												
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																												
C	2014	Suburban	Body	Liftgate Control Module																																																												
C	2014	Suburban	Body	Seat Memory Control Module																																																												
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2014	Suburban	Body	Assist Step Control Module																																																									
C	2014	Suburban	Body	Right Side Object Detection Control Module																																																										
C	2014	Suburban	Body	Left Side Object Detection Control Module																																																										
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																										
C	2014	Suburban	Body	Parking Assist Control Module																																																										
C	2014	Suburban	Body	Theft Deterrent Module																																																										
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																										
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																										
C	2014	Tahoe	Chassis	Suspension Control Module																																																										
C	2014	Tahoe	Body	Body Control Module																																																										
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																										
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Tahoe	Body	Passenger Presence Module																																																										
C	2014	Tahoe	Body	Instrument Cluster																																																										
C	2014	Tahoe	Body	Base Radio																																																										
C	2014	Tahoe	Body	Navigation Radio																																																										
C	2014	Tahoe	Body	Uplevel Radio																																																										
C	2014	Tahoe	Body	Amplifier																																																										
C	2014	Tahoe	Body	Rear Audio Control Module																																																										
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																										
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																										
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Tahoe	Body	Liftgate Control Module																																																										
C	2014	Tahoe	Body	Seat Memory Control Module																																																										
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																																										
C	2014	Tahoe	Body	Assist Step Control Module																																																										
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																																										
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																																										
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																										
C	2014	Tahoe	Body	Parking Assist Control Module																																																										
C	2014	Tahoe	Body	Theft Deterrent Module																																																										
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2015	Captiva (3GN)	Body	Body Control Module																																																											
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																																												
C	2015	Captiva (3GN)	Body	Instrument Cluster																																																												
C	2015	Captiva (3GN)	Body	Radio																																																												
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																												
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																												
C	2015	Captiva (3GN)	Body	HVAC Control Module																																																												
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																												
C	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																												
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																												
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																												
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																												
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																												
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																												
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																												
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																												
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																												
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																												
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																												
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Captiva (Other)	Body	Instrument Cluster																																																												
C	2015	Captiva (Other)	Body	Headlamp Control Module																																																												
C	2015	Captiva (Other)	Body	HVAC Control Module																																																												
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																												
C	2015	Captiva (Other)	Body	Theft Deterrent Module																																																												
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																												
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																											
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																											
C	2015	Cheyenne	Chassis	Power Steering Control Module																																																											
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Cheyenne	Chassis	Suspension Control Module																																																											
C	2015	Cheyenne	Body	Body Control Module																																																											
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Cheyenne	Body	Passenger Presence Module																																																											
C	2015	Cheyenne	Body	Instrument Cluster																																																											
C	2015	Cheyenne	Body	Radio Controls																																																											
C	2015	Cheyenne	Body	HVAC Controls																																																											
C	2015	Cheyenne	Body	Radio																																																											
C	2015	Cheyenne	Body	Amplifier																																																											
C	2015	Cheyenne	Body	Media Disc Player																																																											
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																											
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																											
C	2015	Cheyenne	Body	HVAC Control Module																																																											
C	2015	Cheyenne	Body	Parking Assist Control Module																																																											
C	2015	Cheyenne	Body	Frontview Camera Module																																																											
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																											
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																											
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																											
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																											
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																											
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2015	Silverado	Chassis	Electronic Brake Control Module																																																											
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																											
C	2015	Silverado	Chassis	Power Steering Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Silverado	Chassis	Suspension Control Module																																																											
C	2015	Silverado	Body	Body Control Module																																																										
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Silverado	Body	Passenger Presence Module																																																										
C	2015	Silverado	Body	Instrument Cluster																																																										
C	2015	Silverado	Body	Radio Controls																																																										
C	2015	Silverado	Body	HVAC Controls																																																										
C	2015	Silverado	Body	Radio																																																										
C	2015	Silverado	Body	Amplifier																																																										
C	2015	Silverado	Body	Media Disc Player																																																										
C	2015	Silverado	Body	Human Machine Interface Control Module																																																										
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																										
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2015	Silverado	Body	Parking Assist Control Module																																																										
C	2015	Silverado	Body	Frontview Camera Module																																																										
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Suburban	Chassis	Parking Brake Control Module																																																										
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Suburban	Chassis	Power Steering Control Module																																																										
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Suburban	Chassis	Suspension Control Module																																																										
C	2015	Suburban	Body	Body Control Module																																																										
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Suburban	Body	Passenger Presence Module																																																										
C	2015	Suburban	Body	Instrument Cluster																																																										
C	2015	Suburban	Body	Radio Controls																																																										
C	2015	Suburban	Body	HVAC Controls																																																										
C	2015	Suburban	Body	Radio																																																										
C	2015	Suburban	Body	Amplifier																																																										
C	2015	Suburban	Body	Media Disc Player																																																										
C	2015	Suburban	Body	Human Machine Interface Control Module																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Suburban	Body	HVAC Control Module																																																										
C	2015	Suburban	Body	Liftgate Control Module																																																										
C	2015	Suburban	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2015	Suburban	Body	Assist Step Control Module																																																									
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																										
C	2015	Suburban	Body	Parking Assist Control Module																																																										
C	2015	Suburban	Body	Frontview Camera Module																																																										
C	2015	Suburban	Body	Steering Column Lock Control Module																																																										
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																										
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																										
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																										
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Tahoe	Chassis	Power Steering Control Module																																																										
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Tahoe	Chassis	Suspension Control Module																																																										
C	2015	Tahoe	Body	Body Control Module																																																										
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Tahoe	Body	Passenger Presence Module																																																										
C	2015	Tahoe	Body	Instrument Cluster																																																										
C	2015	Tahoe	Body	Radio Controls																																																										
C	2015	Tahoe	Body	HVAC Controls																																																										
C	2015	Tahoe	Body	Radio																																																										
C	2015	Tahoe	Body	Amplifier																																																										
C	2015	Tahoe	Body	Media Disc Player																																																										
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																										
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																										
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Tahoe	Body	HVAC Control Module																																																										
C	2015	Tahoe	Body	Liftgate Control Module																																																										
C	2015	Tahoe	Body	Keyless Entry Control Module																																																										
C	2015	Tahoe	Body	Assist Step Control Module																																																										
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																										
C	2015	Tahoe	Body	Parking Assist Control Module																																																										
C	2015	Tahoe	Body	Frontview Camera Module																																																										
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																										
C	2015	Tahoe	Body	Battery Energy Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																											
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																											
C	2016	Captiva (3GN)	Body	Body Control Module																																																											
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																											
C	2016	Captiva (3GN)	Body	Radio																																																											
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																											
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																											
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																											
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																											
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																											
C	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																											
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																											
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																											
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																											
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Captiva (Other)	Body	Instrument Cluster																																																											
C	2016	Captiva (Other)	Body	Headlamp Control Module																																																											
C	2016	Captiva (Other)	Body	Radio																																																											
C	2016	Captiva (Other)	Body	HVAC Control Module																																																											
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																											
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																											
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
C	2016	Captiva (Other)	Body	Theft Deterrent Module																																																											
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																										
C	2016	Cheyenne	Chassis	Power Steering Control Module																																																										
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Cheyenne	Chassis	Suspension Control Module																																																										
C	2016	Cheyenne	Body	Body Control Module																																																										
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Cheyenne	Body	Passenger Presence Module																																																										
C	2016	Cheyenne	Body	Instrument Cluster																																																										
C	2016	Cheyenne	Body	Radio Controls																																																										
C	2016	Cheyenne	Body	HVAC Controls																																																										
C	2016	Cheyenne	Body	Radio																																																										
C	2016	Cheyenne	Body	Amplifier																																																										
C	2016	Cheyenne	Body	Media Disc Player																																																										
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																										
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
C	2016	Cheyenne	Body	HVAC Control Module																																																										
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																										
C	2016	Cheyenne	Body	Parking Assist Control Module																																																										
C	2016	Cheyenne	Body	Frontview Camera Module																																																										
C	2016	Cheyenne	Body	Frontview Camera Module																																																										
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Silverado	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2016	Silverado	Chassis	Power Steering Control Module																																																										
C	2016	Silverado	Chassis	Power Steering Control Module																																																											
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Silverado	Chassis	Suspension Control Module																																																											
C	2016	Silverado	Body	Body Control Module																																																											
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Silverado	Body	Passenger Presence Module																																																											
C	2016	Silverado	Body	Instrument Cluster																																																											
C	2016	Silverado	Body	Radio Controls																																																											
C	2016	Silverado	Body	HVAC Controls																																																											
C	2016	Silverado	Body	Radio (IO3)																																																											
C	2016	Silverado	Body	Radio (IOB)																																																											
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																											
C	2016	Silverado	Body	Amplifier																																																											
C	2016	Silverado	Body	Media Disc Player																																																											
C	2016	Silverado	Body	Human Machine Interface Control Module																																																											
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																											
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																											
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																											
C	2016	Silverado	Body	Parking Assist Control Module																																																											
C	2016	Silverado	Body	Frontview Camera Module																																																											
C	2016	Silverado	Body	Frontview Camera Module																																																											
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2016	Suburban	Chassis	Electronic Brake Control Module																																																											
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																											
C	2016	Suburban	Chassis	Parking Brake Control Module																																																											
C	2016	Suburban	Chassis	Power Steering Control Module																																																											
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Suburban	Chassis	Suspension Control Module																																																											
C	2016	Suburban	Body	Body Control Module																																																											
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Suburban	Body	Passenger Presence Module																																																											
C	2016	Suburban	Body	Instrument Cluster																																																											
C	2016	Suburban	Body	Radio Controls																																																											
C	2016	Suburban	Body	HVAC Controls																																																											
C	2016	Suburban	Body	Radio																																																											
C	2016	Suburban	Body	Amplifier																																																											
C	2016	Suburban	Body	Media Disc Player																																																											
C	2016	Suburban	Body	Human Machine Interface Control Module																																																											
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																																											
C	2016	Suburban	Body	HVAC Control Module																																																											
C	2016	Suburban	Body	Liftgate Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																										
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																											
C	2016	Suburban	Body	Keyless Entry Control Module																																																											
C	2016	Suburban	Body	Assist Step Control Module																																																											
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																											
C	2016	Suburban	Body	Parking Assist Control Module																																																											
C	2016	Suburban	Body	Frontview Camera Module																																																											
C	2016	Suburban	Body	Steering Column Lock Control Module																																																											
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																											
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																											
C	2016	Tahoe	Chassis	Power Steering Control Module																																																											
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Tahoe	Chassis	Suspension Control Module																																																											
C	2016	Tahoe	Body	Body Control Module																																																											
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Tahoe	Body	Passenger Presence Module																																																											
C	2016	Tahoe	Body	Instrument Cluster																																																											
C	2016	Tahoe	Body	Radio Controls																																																											
C	2016	Tahoe	Body	HVAC Controls																																																											
C	2016	Tahoe	Body	Radio																																																											
C	2016	Tahoe	Body	Amplifier																																																											
C	2016	Tahoe	Body	Media Disc Player																																																											
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																											
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																											
C	2016	Tahoe	Body	HVAC Control Module																																																											
C	2016	Tahoe	Body	Liftgate Control Module																																																											
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																											
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																											
C	2016	Tahoe	Body	Keyless Entry Control Module																																																											
C	2016	Tahoe	Body	Assist Step Control Module																																																											
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																											
C	2016	Tahoe	Body	Parking Assist Control Module																																																											
C	2016	Tahoe	Body	Frontview Camera Module																																																											
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																											
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																											
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																											
E	2004	ALL	Chassis	Electronic Brake Control Module																																																											
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																											
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																											
E	2006	ALL	Chassis	Electronic Brake Control Module																																																											
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																											
E	2007	ALL	Chassis	Electronic Brake Control Module																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																											
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																											
G	2004	Express/Savana	Chassis	VSES																																																											
G	2004	Express/Savana	Body	Body Control Module																																																											
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																											
G	2004	Express/Savana	Body	OnStar																																																											
G	2004	Express/Savana	Body	Base Radio																																																											
G	2004	Express/Savana	Body	Uplevel Radio																																																											
G	2004	Express/Savana	Body	Remote Function Actuation																																																											
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																											
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																											
G	2004	Express Access/Savana Pro	Chassis	VSES																																																											
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
G	2004	Express Access/Savana Pro	Body	OnStar																																																											
G	2004	Express Access/Savana Pro	Body	Base Radio																																																											
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																											
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																											
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																											
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																											
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																											
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2005	Express/Savana	Chassis	VSES																																																										
G	2005	Express/Savana	Body	Body Control Module																																																										
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2005	Express/Savana	Body	Base Radio																																																										
G	2005	Express/Savana	Body	Uplevel Radio																																																										
G	2005	Express/Savana	Body	Remote Function Actuation																																																										
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2005	Express Access/Savana Pro	Chassis	VSES																																																										
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2005	Express Access/Savana Pro	Body	Base Radio																																																										
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2006	Express/Savana	Chassis	VSES																																																										
G	2006	Express/Savana	Body	Body Control Module																																																										
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2006	Express/Savana	Body	Passenger Presence System																																																										
G	2006	Express/Savana	Body	Base Radio																																																										
G	2006	Express/Savana	Body	Uplevel Radio																																																										
G	2006	Express/Savana	Body	Remote Function Actuation																																																										
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2006	Express Access/Savana Pro	Chassis	VSES																																																										
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2006	Express Access/Savana Pro	Body	Base Radio																																																										
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V									V																																																
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express/Savana	Body	Body Control Module																																																										
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2007	Express/Savana	Body	Passenger Presence System																																																										
G	2007	Express/Savana	Body	Base Radio																																																										
G	2007	Express/Savana	Body	Uplevel Radio																																																										
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V									V																																																
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2007	Express Access/Savana Pro	Body	Radio																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V																																																									
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V																																																									
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																												
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2008	Express/Savana	Body	Passenger Presence System																																										V	V															
G	2008	Express/Savana	Body	Radio																																																										
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express/Savana	Body	Rollover Sensor																																																										
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																										V								V								
G	2008	Express/Savana	Body	Theft Deterrent Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V																																																									
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V																																																									
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																											
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																										V	V														
G	2008	Express Access/Savana Pro	Body	Radio																																																										
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								V									V							
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																							
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																							
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																												
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2009	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2009	Express/Savana	Body	Passenger Presence System																																								V	V														
G	2009	Express/Savana	Body	Radio																																																										
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2009	Express/Savana	Body	Rollover Sensor																																																											
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																								V									V							
G	2009	Express/Savana	Body	Theft Deterrent Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																							
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																							
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																												
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2009	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V															
G	2009	Express Access/Savana Pro	Body	Radio																																																										
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V							
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																											
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																									
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module		V																																																									
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																													
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																	
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2010	Express/Savana	Body	Passenger Presence System																																									V	V															
G	2010	Express/Savana	Body	Radio																																																											
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2010	Express/Savana	Body	Rollover Sensor																																																												
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																									V									V							
G	2010	Express/Savana	Body	Theft Deterrent Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																								
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																									
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module		V																																																									
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																													
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2010	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																										V	V																
G	2010	Express Access/Savana Pro	Body	Radio																																																											
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																										V										V						
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																							
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																									
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																											
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																									
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																													
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2011	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																
G	2011	Express/Savana	Body	Digital Radio Receiver																																																											
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2011	Express/Savana	Body	Passenger Presence System																																										V	V																
G	2011	Express/Savana	Body	Radio																																																											
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2011	Express/Savana	Body	Rollover Sensor																																																											
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																										V										V							
G	2011	Express/Savana	Body	Theft Deterrent Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																							
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																									
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																								
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																											
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2011	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V																
G	2011	Express Access/Savana Pro	Body	Radio																																																										
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V						
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																							
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																									
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																											
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																									
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																													
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2012	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																
G	2012	Express/Savana	Body	Digital Radio Receiver																																																											
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2012	Express/Savana	Body	Passenger Presence System																																									V	V																
G	2012	Express/Savana	Body	Radio																																																										
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2012	Express/Savana	Body	Rollover Sensor																																																											
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																									V									V						
G	2012	Express/Savana	Body	Theft Deterrent Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																							
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																								
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																												
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2012	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																												V	V													
G	2012	Express Access/Savana Pro	Body	Radio																																																										
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																												V									V					
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																								
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																												
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2013	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
G	2013	Express/Savana	Body	Digital Radio Receiver																																																										
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2013	Express/Savana	Body	Navigation Radio																																																										
G	2013	Express/Savana	Body	Park Assist Module																																							V	V	V																	
G	2013	Express/Savana	Body	Passenger Presence System																																										V	V															
G	2013	Express/Savana	Body	Radio																																																										
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2013	Express/Savana	Body	Rollover Sensor																																																										
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																										V										V						
G	2013	Express/Savana	Body	Theft Deterrent Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																											
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																									
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																												
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2013	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																											
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																											
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																							V	V	V																		
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																										V	V															
G	2013	Express Access/Savana Pro	Body	Radio																																																											
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V										V						
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																												
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
G	2014	Express	Chassis	Electronic Brake Control Module																																																												
G	2014	Express	Body	Body Control Module																																																											
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2014	Express	Body	Passenger Presence Module																																																												
G	2014	Express	Body	Rollover Sensor Module																																																												
G	2014	Express	Body	Instrument Cluster																																																												
G	2014	Express	Body	Chime Alarm Control Module																																																												
G	2014	Express	Body	Base Radio																																																											
G	2014	Express	Body	Navigation Radio																																																											
G	2014	Express	Body	Uplevel Radio																																																											
G	2014	Express	Body	Digital Radio Receiver Control Module																																																												
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																												
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																												
G	2014	Express	Body	Auxiliary Heater Control Module																																																												
G	2014	Express	Body	Remote Control Door Lock Receiver																																																												
G	2014	Express	Body	Parking Assist Control Module																																																												
G	2014	Express	Body	Theft Deterrent Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2014	Savana	Chassis	Electronic Brake Control Module																																																										
G	2014	Savana	Body	Body Control Module																																																									
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2014	Savana	Body	Passenger Presence Module																																																										
G	2014	Savana	Body	Rollover Sensor Module																																																										
G	2014	Savana	Body	Instrument Cluster																																																									
G	2014	Savana	Body	Chime Alarm Control Module																																																										
G	2014	Savana	Body	Base Radio																																																										
G	2014	Savana	Body	Navigation Radio																																																										
G	2014	Savana	Body	Uplevel Radio																																																										
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2014	Savana	Body	Auxiliary Heater Control Module																																																										
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
G	2014	Savana	Body	Parking Assist Control Module																																																										
G	2014	Savana	Body	Theft Deterrent Module																																																										
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2015	Express	Chassis	Electronic Brake Control Module																																																										
G	2015	Express	Body	Body Control Module																																																										
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2015	Express	Body	Rollover Sensor Module																																																										
G	2015	Express	Body	Instrument Cluster																																																										
G	2015	Express	Body	Digital Radio Receiver Control Module																																																										
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2015	Express	Body	Auxiliary Heater Control Module																																																										
G	2015	Express	Body	Remote Control Door Lock Receiver																																																										
G	2015	Express	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2015	Express	Body	Theft Deterrent Module																																																										
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2015	Savana	Chassis	Electronic Brake Control Module																																																										
G	2015	Savana	Body	Body Control Module																																																									
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
G	2015	Savana	Body	Rollover Sensor Module																																																									
G	2015	Savana	Body	Instrument Cluster																																																									
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																									
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																									
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																									
G	2015	Savana	Body	Auxiliary Heater Control Module																																																									
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																									
G	2015	Savana	Body	Parking Assist Control Module																																																									
G	2015	Savana	Body	Theft Deterrent Module																																																									
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
G	2016	Express	Chassis	Electronic Brake Control Module																																																									
G	2016	Express	Body	Body Control Module																																																									
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
G	2016	Express	Body	Instrument Cluster																																																									
G	2016	Express	Body	Chime Alarm Control Module																																																									
G	2016	Express	Body	Base Radio																																																									
G	2016	Express	Body	Navigation Radio																																																									
G	2016	Express	Body	Uplevel Radio																																																									
G	2016	Express	Body	Digital Radio Receiver Control Module																																																									
G	2016	Express	Body	Telematics Communication Interface Control Module																																																									
G	2016	Express	Body	Auxiliary Heater Control Module																																																									
G	2016	Express	Body	Remote Control Door Lock Receiver																																																									
G	2016	Express	Body	Parking Assist Control Module																																																									
G	2016	Express	Body	Theft Deterrent Module																																																									
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2016	Savana	Chassis	Electronic Brake Control Module																																																										
G	2016	Savana	Body	Body Control Module																																																									
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2016	Savana	Body	Instrument Cluster																																																									
G	2016	Savana	Body	Chime Alarm Control Module																																																									
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																									
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																									
G	2016	Savana	Body	Auxiliary Heater Control Module																																																									
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																									
G	2016	Savana	Body	Parking Assist Control Module																																																									
G	2016	Savana	Body	Theft Deterrent Module																																																									
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2004	Express/Savana	Chassis	VSES																																																									
H	2004	Express/Savana	Body	Body Control Module																																																									
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2004	Express/Savana	Body	OnStar																																																									
H	2004	Express/Savana	Body	Base Radio																																																									
H	2004	Express/Savana	Body	Uplevel Radio																																																									
H	2004	Express/Savana	Body	Remote Function Actuation																																																									
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
H	2004	Express Access/Savana Pro	Chassis	VSES																																																									
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2004	Express Access/Savana Pro	Body	OnStar																																																									
H	2004	Express Access/Savana Pro	Body	Base Radio																																																									
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2005	Express/Savana	Chassis	VSES																																																									
H	2005	Express/Savana	Body	Body Control Module																																																									
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2005	Express/Savana	Body	Base Radio																																																									
H	2005	Express/Savana	Body	Uplevel Radio																																																									
H	2005	Express/Savana	Body	Remote Function Actuation																																																									
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2005	Express Access/Savana Pro	Chassis	VSES																																																												
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2005	Express Access/Savana Pro	Body	Base Radio																																																												
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																												
H	2006	Express/Savana	Chassis	VSES																																																												
H	2006	Express/Savana	Body	Body Control Module																																																												
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																												
H	2006	Express/Savana	Body	Passenger Presence System																																																												
H	2006	Express/Savana	Body	Base Radio																																																												
H	2006	Express/Savana	Body	Uplevel Radio																																																												
H	2006	Express/Savana	Body	Remote Function Actuation																																																												
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2006	Express Access/Savana Pro	Chassis	VSES																																																												
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2006	Express Access/Savana Pro	Body	Base Radio																																																												
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express/Savana	Body	Body Control Module																																																										
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2007	Express/Savana	Body	Passenger Presence System																																																										
H	2007	Express/Savana	Body	Base Radio																																																										
H	2007	Express/Savana	Body	Uplevel Radio																																																										
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2007	Express Access/Savana Pro	Body	Base Radio																																																										
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V																																																									
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V																																																									
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																												
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2008	Express/Savana	Body	Passenger Presence System																																											V	V														
H	2008	Express/Savana	Body	Radio																																																										
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express/Savana	Body	Rollover Sensor																																																										
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																											V									V						
H	2008	Express/Savana	Body	Theft Deterrent Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V																																																									
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V																																																									
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																												
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																										V	V															
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																										V									V							
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																						
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																												
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																										V	V															
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																										V									V							
H	2009	Express/Savana	Body	Theft Deterrent Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																						
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																												
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																										V	V															
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V					
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																							
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																			
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																					
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																			
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																							
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																			
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																					
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																									
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
H	2010	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																													
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2010	Express/Savana	Body	Passenger Presence System																																									V	V														
H	2010	Express/Savana	Body	Radio																																																							
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
H	2010	Express/Savana	Body	Rollover Sensor																																																							
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																									V									V						
H	2010	Express/Savana	Body	Theft Deterrent Module																																																							
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																			
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																					
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																			
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																			
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																					
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																									
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																							
H	2010	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																													
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V														
H	2010	Express Access/Savana Pro	Body	Radio																																																							
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																							
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V						
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																							
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																			
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																					
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																			
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																			
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																					
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																			
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																					
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																									
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
H	2011	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																													
H	2011	Express/Savana	Body	Digital Radio Receiver																																																							
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																							
H	2011	Express/Savana	Body	Passenger Presence System																																									V	V														

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2011	Express/Savana	Body	Radio																																																										
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2011	Express/Savana	Body	Rollover Sensor																																																										
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																										V								V						
H	2011	Express/Savana	Body	Theft Deterrent Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																												
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2011	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																										V	V															
H	2011	Express Access/Savana Pro	Body	Radio																																																										
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																										V								V						
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																												
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2012	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
H	2012	Express/Savana	Body	Digital Radio Receiver																																																										
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2012	Express/Savana	Body	Passenger Presence System																																										V	V															
H	2012	Express/Savana	Body	Radio																																																										
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2012	Express/Savana	Body	Rollover Sensor																																																										
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																										V								V						
H	2012	Express/Savana	Body	Theft Deterrent Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																					
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																							
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																										
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2012	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																														
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2012	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V															
H	2012	Express Access/Savana Pro	Body	Radio																																																									
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V						
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																								
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																											
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2013	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																														
H	2013	Express/Savana	Body	Digital Radio Receiver																																																										
H	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2013	Express/Savana	Body	Navigation Radio																																																										
H	2013	Express/Savana	Body	Park Assist Module																																							V	V	V																	
H	2013	Express/Savana	Body	Passenger Presence System																																									V	V															
H	2013	Express/Savana	Body	Radio																																																									
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2013	Express/Savana	Body	Rollover Sensor																																																										
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																									V									V						
H	2013	Express/Savana	Body	Theft Deterrent Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																								
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																											
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2013	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																														
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																								V	V	V															
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																											V	V													
H	2013	Express Access/Savana Pro	Body	Radio																																																									
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V						
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2014	Express	Chassis	Electronic Brake Control Module																																																										
H	2014	Express	Body	Body Control Module																																																									
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Express	Body	Passenger Presence Module																																																										
H	2014	Express	Body	Rollover Sensor Module																																																										
H	2014	Express	Body	Instrument Cluster																																																									
H	2014	Express	Body	Chime Alarm Control Module																																																										
H	2014	Express	Body	Base Radio																																																										
H	2014	Express	Body	Navigation Radio																																																										
H	2014	Express	Body	Uplevel Radio																																																										
H	2014	Express	Body	Digital Radio Receiver Control Module																																																										
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2014	Express	Body	Auxiliary Heater Control Module																																																										
H	2014	Express	Body	Remote Control Door Lock Receiver																																																										
H	2014	Express	Body	Parking Assist Control Module																																																										
H	2014	Express	Body	Theft Deterrent Module																																																										
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2014	Savana	Chassis	Electronic Brake Control Module																																																											
H	2014	Savana	Body	Body Control Module																																																										
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Savana	Body	Passenger Presence Module																																																										
H	2014	Savana	Body	Rollover Sensor Module																																																										
H	2014	Savana	Body	Instrument Cluster																																																										
H	2014	Savana	Body	Chime Alarm Control Module																																																										
H	2014	Savana	Body	Base Radio																																																										
H	2014	Savana	Body	Navigation Radio																																																										
H	2014	Savana	Body	Uplevel Radio																																																										
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2014	Savana	Body	Auxiliary Heater Control Module																																																										
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2014	Savana	Body	Parking Assist Control Module																																																										
H	2014	Savana	Body	Theft Deterrent Module																																																										
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2015	Express	Chassis	Electronic Brake Control Module																																																										
H	2015	Express	Body	Body Control Module																																																										
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Express	Body	Rollover Sensor Module																																																										
H	2015	Express	Body	Instrument Cluster																																																										
H	2015	Express	Body	Digital Radio Receiver Control Module																																																										
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2015	Express	Body	Auxiliary Heater Control Module																																																										
H	2015	Express	Body	Remote Control Door Lock Receiver																																																										
H	2015	Express	Body	Parking Assist Control Module																																																										
H	2015	Express	Body	Theft Deterrent Module																																																										
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2015	Savana	Chassis	Electronic Brake Control Module																																																										
H	2015	Savana	Body	Body Control Module																																																										
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2015	Savana	Body	Rollover Sensor Module																																																										
H	2015	Savana	Body	Instrument Cluster																																																										
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2015	Savana	Body	Auxiliary Heater Control Module																																																										
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2015	Savana	Body	Parking Assist Control Module																																																										
H	2015	Savana	Body	Theft Deterrent Module																																																										
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2016	Express	Chassis	Electronic Brake Control Module																																																										
H	2016	Express	Body	Body Control Module																																																										
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Express	Body	Instrument Cluster																																																										
H	2016	Express	Body	Chime Alarm Control Module																																																										
H	2016	Express	Body	Base Radio																																																										
H	2016	Express	Body	Navigation Radio																																																										
H	2016	Express	Body	Uplevel Radio																																																										
H	2016	Express	Body	Digital Radio Receiver Control Module																																																										
H	2016	Express	Body	Telematics Communication Interface Control Module																																																										
H	2016	Express	Body	Auxiliary Heater Control Module																																																										
H	2016	Express	Body	Remote Control Door Lock Receiver																																																										
H	2016	Express	Body	Parking Assist Control Module																																																										
H	2016	Express	Body	Theft Deterrent Module																																																										
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2016	Savana	Chassis	Electronic Brake Control Module																																																										
H	2016	Savana	Body	Body Control Module																																																										
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Savana	Body	Instrument Cluster																																																										
H	2016	Savana	Body	Chime Alarm Control Module																																																										
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
H	2016	Savana	Body	Auxiliary Heater Control Module																																																										
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2016	Savana	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2016	Savana	Body	Theft Deterrent Module																																																										
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																										
J	2004	ALL	Chassis	Electronic Brake Control Module																																																										
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
J	2007	ALL	Chassis	Electronic Brake Control Module																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V			V																																																						
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V			V																																																						
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer	V			V																																																						
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer	V			V																																																						
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																										
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Tracker	Chassis	Power Steering Control Module																																																										
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Tracker	Body	Body Control Module																																																										
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Tracker	Body	Passenger Presence Module																																																										
J	2013	Tracker	Body	Instrument Cluster																																																										
J	2013	Tracker	Body	Radio																																																										
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																																										
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Tracker	Body	Front Seat Heating Control Module																																																										
J	2013	Tracker	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2013	Tracker	Body	Frontview Camera Module																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V			V																																																						
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V			V																																																						
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer	V			V																																																						
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer	V			V																																																						
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2013	Trax	Chassis	Electronic Brake Control Module																																																										
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Trax	Chassis	Power Steering Control Module																																																										
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Trax	Body	Body Control Module																																																										
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Trax	Body	Passenger Presence Module																																																										
J	2013	Trax	Body	Instrument Cluster																																																										
J	2013	Trax	Body	Radio																																																										
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Trax	Body	Front Seat Heating Control Module																																																										
J	2013	Trax	Body	Parking Assist Control Module																																																										
J	2013	Trax	Body	Frontview Camera Module																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission	V																																																										
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission	V																																																										
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																											
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																											
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																											
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V			V																																																							
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V			V																																																							
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer	V			V																																																							
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer	V			V																																																							
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																											
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																											
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																																											
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																											
J	2014	Tracker	Chassis	Power Steering Control Module																																																											
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2014	Tracker	Body	Body Control Module																																																											
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2014	Tracker	Body	Passenger Presence Module																																																											
J	2014	Tracker	Body	Instrument Cluster																																																											
J	2014	Tracker	Body	Radio																																																										
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																																											
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																																											
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																																											
J	2014	Tracker	Body	Front Seat Heating Control Module																																																											
J	2014	Tracker	Body	Parking Assist Control Module																																																											
J	2014	Tracker	Body	Frontview Camera Module																																																											
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																											
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																											
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V			V																																																							
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V			V																																																							
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																												
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
J	2014	Trax	Chassis	Electronic Brake Control Module																																																												
J	2014	Trax	Chassis	Power Steering Control Module																																																												
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Trax	Body	Body Control Module																																																												
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Trax	Body	Passenger Presence Module																																																												
J	2014	Trax	Body	Instrument Cluster																																																												
J	2014	Trax	Body	Radio																																																												
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Trax	Body	Front Seat Heating Control Module																																																												
J	2014	Trax	Body	Parking Assist Control Module																																																												
J	2014	Trax	Body	Frontview Camera Module																																																												
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																											
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																											
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																											
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V			V																																																							
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V			V																																																							
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer	V			V																																																						
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer	V			V																																																						
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2015	Tracker	Chassis	Power Steering Control Module																																																										
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Tracker	Body	Body Control Module																																																										
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Tracker	Body	Instrument Cluster																																																										
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																																										
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Tracker	Body	Front Seat Heating Control Module																																																										
J	2015	Tracker	Body	Parking Assist Control Module																																																										
J	2015	Tracker	Body	Frontview Camera Module																																																										
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission	V			V																																																						
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission	V			V																																																						
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2015	Trax	Powertrain	Chassis Control Module																																																										
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Trax	Chassis	Electronic Brake Control Module																																																										
J	2015	Trax	Chassis	Power Steering Control Module																																																										
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Trax	Body	Body Control Module																																																									
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Trax	Body	Passenger Presence Module																																																										
J	2015	Trax	Body	Instrument Cluster																																																										
J	2015	Trax	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Trax	Body	Seat Memory Control Module																																																										
J	2015	Trax	Body	Front Seat Heating Control Module																																																										
J	2015	Trax	Body	Right Side Object Detection Control Module																																																										
J	2015	Trax	Body	Left Side Object Detection Control Module																																																										
J	2015	Trax	Body	Parking Assist Control Module																																																										
J	2015	Trax	Body	Frontview Camera Module																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer	V			V																																																						
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer	V			V																																																						
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																										
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2016	Tracker	Chassis	Power Steering Control Module																																																										
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Tracker	Body	Body Control Module																																																										
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Tracker	Body	Instrument Cluster																																																										
J	2016	Tracker	Body	Trailer Interface Control Module																																																										
J	2016	Tracker	Body	Radio																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Tracker	Body	Front Seat Heating Control Module																																																										
J	2016	Tracker	Body	Parking Assist Control Module																																																										
J	2016	Tracker	Body	Frontview Camera Module																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2016	Trax	Powertrain	Chassis Control Module																																																										
J	2016	Trax	Chassis	Electronic Brake Control Module																																																										
J	2016	Trax	Chassis	Power Steering Control Module																																																										
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Trax	Body	Body Control Module																																																										
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Trax	Body	Passenger Presence Module																																																										
J	2016	Trax	Body	Instrument Cluster																																																										
J	2016	Trax	Body	Trailer Interface Control Module																																																										
J	2016	Trax	Body	Radio																																																										
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Trax	Body	Seat Memory Control Module																																																										
J	2016	Trax	Body	Front Seat Heating Control Module																																																										
J	2016	Trax	Body	Right Side Object Detection Control Module																																																										
J	2016	Trax	Body	Left Side Object Detection Control Module																																																										
J	2016	Trax	Body	Parking Assist Control Module																																																										
J	2016	Trax	Body	Frontview Camera Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case											V																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case											V																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case											V																																															
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case											V																																															
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case											V																																															
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable											V																																															
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control											V																																															

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable											V																																																	
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable											V																																																	
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control											V																																																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable											V																																																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable											V																																																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control											V																																																	
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case											V																																																	
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case											V																																																	
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable											V																																																	
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable											V																																																	
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
K	2004	ALL	Chassis	ESC																																																											
K	2004	ALL	Chassis	Rear Wheel Steering																																																												
K	2004	ALL	Chassis	Tire Pressure Monitor																																																												
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																												
K	2004	ALL	Chassis	VSES																																																											
K	2004	ALL	Body	Amplifier (Bose)																																																												
K	2004	ALL	Body	Body Control Module																																																											
K	2004	ALL	Body	CD Changer																																																											
K	2004	ALL	Body	Chime																																																											
K	2004	ALL	Body	Driver Door Module																																																											
K	2004	ALL	Body	Driver Seat Module																																																											
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2004	ALL	Body	Instrument Panel Cluster																																																											
K	2004	ALL	Body	OnStar																																																											
K	2004	ALL	Body	Passenger Door Module																																																											
K	2004	ALL	Body	Passenger Presence System																																																											
K	2004	ALL	Body	Radio Base																																																											
K	2004	ALL	Body	Radio Uplevel																																																											
K	2004	ALL	Body	Radio Navigation																																																											
K	2004	ALL	Body	Rear Aux. Climate Module																																																												
K	2004	ALL	Body	Rear HVAC																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2004	ALL	Body	Rear Seat Audio																																																										
K	2004	ALL	Body	Rear Seat Entertainment																																																											
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2004	ALL	Body	Vehicle Theft Deterrent																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC											V																																															
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC											V																																																
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC											V																																																
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case											V																																																
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case											V																																																
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																											
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case											V																																																
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable											V																																																
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control											V																																																
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable											V																																																
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable											V																																																
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control											V																																																
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable											V																																																
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable											V																																																
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control											V																																																
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case											V																																																
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																											
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																											
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable											V																																																
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable											V																																																
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2005	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC											V																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC											V																																														
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case											V																																														
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case											V																																														
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case											V																																																
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable											V																																																
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control											V																																																
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable											V																																																
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable											V																																																
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control											V																																																
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable											V																																																
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable											V																																																
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control											V																																																
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable											V																																																
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable											V																																																
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module					V																																																						
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module			V																																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case											V																																																
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																						
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module			V																																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case											V																																																
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed			V																																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable											V																																																
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable											V																																																
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
K	2006	ALL	Chassis	ESC																																																											
K	2006	ALL	Chassis	Tire Pressure Monitor																																																												
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																												
K	2006	ALL	Chassis	VSES																																																											
K	2006	ALL	Body	Amplifier (Bose)																																																												
K	2006	ALL	Body	Body Control Module																																																												
K	2006	ALL	Body	CD Changer																																																												
K	2006	ALL	Body	Chime																																																												
K	2006	ALL	Body	Disc Player and Video Display																																																												
K	2006	ALL	Body	Driver Door Module																																																												
K	2006	ALL	Body	Driver Seat Module																																																												
K	2006	ALL	Body	Generator Battery Control Module																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2006	ALL	Body	Instrument Panel Cluster																																																									
K	2006	ALL	Body	Passenger Door Module																																																									
K	2006	ALL	Body	Passenger Presence System																																																									
K	2006	ALL	Body	Base Radio																																																									
K	2006	ALL	Body	Uplevel Radio																																																									
K	2006	ALL	Body	Navigation Radio																																																									
K	2006	ALL	Body	Rear Aux. Climate Module																																																									
K	2006	ALL	Body	Rear HVAC																																																									
K	2006	ALL	Body	Rear Seat Audio																																																									
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2006	ALL	Body	Vehicle Theft Deterrent																																																									
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																					
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																														
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module				V																																																					
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																														
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																					
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																														
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module				V																																																					
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																														
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Avalanche	Chassis	Electronic Suspension Control																																																									
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																																									
K	2007	Avalanche	Body	Amplifier (Bose)																																																									
K	2007	Avalanche	Body	Assist Step Controller																																																									
K	2007	Avalanche	Body	Body Control Module														V	V	V	V	V	V	V		V	V			V																															
K	2007	Avalanche	Body	Body Control Module (aux.)																																																									
K	2007	Avalanche	Body	Digital Radio Receiver																																																									
K	2007	Avalanche	Body	Driver Door Switch																																																									
K	2007	Avalanche	Body	HVAC Control Module Auto																											V	V																													
K	2007	Avalanche	Body	HVAC Control Module Manual																												V																													
K	2007	Avalanche	Body	Instrument Panel Cluster																																																									
K	2007	Avalanche	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
K	2007	Avalanche	Body	Park Assist Module																																						V	V	V																	
K	2007	Avalanche	Body	Passenger Door Switch																																																									
K	2007	Avalanche	Body	Passenger Presence System																																									V																
K	2007	Avalanche	Body	Radio																																																									
K	2007	Avalanche	Body	Rear Heated Seat Module																																V				V																					
K	2007	Avalanche	Body	Rear HVAC/RSA																																																									
K	2007	Avalanche	Body	Rollover Sensor																																																									
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																																									V									V							
K	2007	Avalanche	Body	Theft Deterrent Module																																																									
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																					

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																															
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module				V																																																						
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																															
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																						
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																															
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module											V																																															
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module				V																																																						
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																															
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Suburban	Chassis	Electronic Suspension Control																																																										
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																										
K	2007	Suburban	Body	Amplifier (Bose)																																																										
K	2007	Suburban	Body	Assist Step Controller																																																										
K	2007	Suburban	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
K	2007	Suburban	Body	Body Control Module (aux.)																																																										
K	2007	Suburban	Body	Digital Radio Receiver																																																										
K	2007	Suburban	Body	Driver Door Switch																																																										
K	2007	Suburban	Body	HVAC Control Module Auto																												V	V																														
K	2007	Suburban	Body	HVAC Control Module Manual																													V																														
K	2007	Suburban	Body	Instrument Panel Cluster																																																										
K	2007	Suburban	Body	Lift Gate Module																																																										
K	2007	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2007	Suburban	Body	Park Assist Module																																							V	V	V																	
K	2007	Suburban	Body	Passenger Door Switch																																																										
K	2007	Suburban	Body	Passenger Presence System																																									V																	
K	2007	Suburban	Body	Radio																																																										
K	2007	Suburban	Body	Rear Heated Seat Module																																	V				V																					
K	2007	Suburban	Body	Rear HVAC/RSA																																																										
K	2007	Suburban	Body	Rollover Sensor																																																										
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																									V										V					
K	2007	Suburban	Body	Theft Deterrent Module																																																										
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V																																																						
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																															
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module				V																																																						
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module											V																																															
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																							
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																																
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module				V																																																							
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																																

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																						
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																															
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																						
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module											V																																															
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module											V																																															
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module				V																																																						
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																															
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module											V																																															
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																							
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Silverado	Chassis	Electronic Suspension Control																																																										
K	2007	Silverado	Chassis	Trailer Brake Control Module																																																										
K	2007	Silverado	Body	Amplifier (Bose)																																																										
K	2007	Silverado	Body	Body Control Module														V	V	V	V	V	V	V		V	V			V																																
K	2007	Silverado	Body	Body Control Module (aux.)																																																										
K	2007	Silverado	Body	Digital Radio Receiver																																																										
K	2007	Silverado	Body	Driver Door Switch																																																										
K	2007	Silverado	Body	HVAC Control Module Auto																												V	V																													
K	2007	Silverado	Body	HVAC Control Module Manual																													V																													
K	2007	Silverado	Body	Instrument Panel Cluster																																																										
K	2007	Silverado	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2007	Silverado	Body	Park Assist Module																																						V	V	V																		
K	2007	Silverado	Body	Passenger Door Switch																																																										
K	2007	Silverado	Body	Passenger Presence System																																									V																	
K	2007	Silverado	Body	Radio																																																										
K	2007	Silverado	Body	Rear Heated Seat Module																																	V				V																					
K	2007	Silverado	Body	Rear HVAC/RSA																																																										
K	2007	Silverado	Body	Rollover Sensor																																																										
K	2007	Silverado	Body	Supplemental Inflatable Restraint																																									V									V								
K	2007	Silverado	Body	Theft Deterrent Module																																																										
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module				V																																																						
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module											V																																															
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																						
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																															
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																						

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																															
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2007	Tahoe	Body	Amplifier (Bose)																																																										
K	2007	Tahoe	Body	Assist Step Controller																																																										
K	2007	Tahoe	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
K	2007	Tahoe	Body	Body Control Module (aux.)																																																										
K	2007	Tahoe	Body	Digital Radio Receiver																																																										
K	2007	Tahoe	Body	Driver Door Switch																																																										
K	2007	Tahoe	Body	HVAC Control Module Auto																												V	V																														
K	2007	Tahoe	Body	HVAC Control Module Manual																													V																														
K	2007	Tahoe	Body	Instrument Panel Cluster																																																										
K	2007	Tahoe	Body	Lift Gate Module																																																										
K	2007	Tahoe	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																				
K	2007	Tahoe	Body	Park Assist Module																																							V	V	V																	
K	2007	Tahoe	Body	Passenger Door Switch																																																										
K	2007	Tahoe	Body	Passenger Presence System																																										V																
K	2007	Tahoe	Body	Radio																																																										
K	2007	Tahoe	Body	Rear Heated Seat Module																																	V				V																					
K	2007	Tahoe	Body	Rear HVAC/RSA																																																										
K	2007	Tahoe	Body	Rollover Sensor																																																										
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																										V									V						
K	2007	Tahoe	Body	Theft Deterrent Module																																																										
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																																
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																																
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																							
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																																
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																							
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																																
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2008	Avalanche	Chassis	Electronic Brake Control Module																																																											
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																											
K	2008	Avalanche	Body	Amplifier (Bose)																																																											
K	2008	Avalanche	Body	Assist Step Controller																																																											
K	2008	Avalanche	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																															
K	2008	Avalanche	Body	Body Control Module (aux.)																																																											
K	2008	Avalanche	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2008	Avalanche	Body	Driver Door Switch																																																									
K	2008	Avalanche	Body	HVAC Control Module Auto																												V	V																												
K	2008	Avalanche	Body	HVAC Control Module Manual																													V																													
K	2008	Avalanche	Body	Instrument Panel Cluster																																																									
K	2008	Avalanche	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
K	2008	Avalanche	Body	Park Assist Module																																							V	V	V																
K	2008	Avalanche	Body	Passenger Door Switch																																																									
K	2008	Avalanche	Body	Passenger Presence System																																										V															
K	2008	Avalanche	Body	Radio																																																									
K	2008	Avalanche	Body	Rear Heated Seat Module																																	V			V																					
K	2008	Avalanche	Body	Rear HVAC/RSA																																																									
K	2008	Avalanche	Body	Rollover Sensor																																																									
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																									V									V						
K	2008	Avalanche	Body	Theft Deterrent Module																																																									
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																					
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																														
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module				V																																																					
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																														
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																					
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																														
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																					
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module											V																																														
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																							
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																					
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																														
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2008	Suburban	Chassis	EBCM Under 8600 GVW																																																									
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW														V																																										
K	2008	Suburban	Chassis	Electronic Suspension Control																																																									
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																									
K	2008	Suburban	Body	Amplifier (Bose)																																																									
K	2008	Suburban	Body	Assist Step Controller																																																									
K	2008	Suburban	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																														
K	2008	Suburban	Body	Body Control Module (aux.)																																																									
K	2008	Suburban	Body	Digital Radio Receiver																																																									
K	2008	Suburban	Body	Driver Door Switch																																																									
K	2008	Suburban	Body	HVAC Control Module Auto																												V	V																													
K	2008	Suburban	Body	HVAC Control Module Manual																													V																													
K	2008	Suburban	Body	Instrument Panel Cluster																																																									
K	2008	Suburban	Body	Lift Gate Module																																																									
K	2008	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
K	2008	Suburban	Body	Park Assist Module																																							V	V	V																
K	2008	Suburban	Body	Passenger Door Switch																																																									
K	2008	Suburban	Body	Passenger Presence System																																										V															

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2008	Suburban	Body	Radio																																																										
K	2008	Suburban	Body	Rear Heated Seat Module																																	V				V																					
K	2008	Suburban	Body	Rear HVAC/RSA																																																										
K	2008	Suburban	Body	Rollover Sensor																																																										
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																									V									V						
K	2008	Suburban	Body	Theft Deterrent Module																																																										
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V																																																						
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																															
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																							
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module											V																																																
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																																
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																																
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																							
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																																
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V			V																																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module											V																																																
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																								
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module											V																																																
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																										
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																																
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module											V																																																
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																								
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2008	Silverado	Chassis	Electronic Suspension Control																																																												
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																												
K	2008	Silverado	Body	Amplifier (Bose)																																																												
K	2008	Silverado	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																																
K	2008	Silverado	Body	Body Control Module (aux.)																																																												
K	2008	Silverado	Body	Digital Radio Receiver																																																												
K	2008	Silverado	Body	Driver Door Switch																																																												
K	2008	Silverado	Body	HVAC Control Module Auto																												V	V																															
K	2008	Silverado	Body	HVAC Control Module Manual																													V																															

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2008	Silverado	Body	Instrument Panel Cluster																																																									
K	2008	Silverado	Body	Memory Seat Module																														V	V	V	V	V	V	V																					
K	2008	Silverado	Body	Park Assist Module																																						V	V	V																	
K	2008	Silverado	Body	Passenger Door Switch																																																									
K	2008	Silverado	Body	Passenger Presence System																																									V																
K	2008	Silverado	Body	Radio																																																									
K	2008	Silverado	Body	Rear Heated Seat Module																																	V				V																				
K	2008	Silverado	Body	Rear HVAC/RSA																																																									
K	2008	Silverado	Body	Rollover Sensor																																																									
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																									V									V						
K	2008	Silverado	Body	Theft Deterrent Module																																																									
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																					
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																					
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																														
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																					
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																														
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
K	2008	Tahoe	Chassis	Electronic Brake Control Module																																																									
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																									
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																									
K	2008	Tahoe	Body	Amplifier (Bose)																																																									
K	2008	Tahoe	Body	Assist Step Controller																																																									
K	2008	Tahoe	Body	Body Control Module														V	V	V	V	V	V	V	V	V	V			V																															
K	2008	Tahoe	Body	Body Control Module (aux.)																																																									
K	2008	Tahoe	Body	Digital Radio Receiver																																																									
K	2008	Tahoe	Body	Driver Door Switch																																																									
K	2008	Tahoe	Body	HVAC Control Module Auto																												V	V																												
K	2008	Tahoe	Body	HVAC Control Module Manual																													V																												
K	2008	Tahoe	Body	Instrument Panel Cluster																																																									
K	2008	Tahoe	Body	Lift Gate Module																																																									
K	2008	Tahoe	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
K	2008	Tahoe	Body	Park Assist Module																																						V	V	V																	
K	2008	Tahoe	Body	Passenger Door Switch																																																									
K	2008	Tahoe	Body	Passenger Presence System																																									V																
K	2008	Tahoe	Body	Radio																																																									
K	2008	Tahoe	Body	Rear Heated Seat Module																																	V				V																				
K	2008	Tahoe	Body	Rear HVAC/RSA																																																									
K	2008	Tahoe	Body	Rollover Sensor																																																									
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																									V									V						
K	2008	Tahoe	Body	Theft Deterrent Module																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																					
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																		

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																							
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module											V																																														
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2008	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																															
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2008	Tahoe Hybrid	Body	HVAC Control Module																												V	V																														
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2008	Tahoe Hybrid	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2008	Tahoe Hybrid	Body	Park Assist Module																																						V	V	V																		
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																									V																	
K	2008	Tahoe Hybrid	Body	Radio																																																										
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																	V				V																					
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																										
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																									V											V					
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																															
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed		V																																																							
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																															
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed		V																																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																						
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																															
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed		V																																																								
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																						
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																															
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module		V																																																								
K	2009	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																									
K	2009	Avalanche	Body	Amplifier (Bose)																																																										
K	2009	Avalanche	Body	Assist Step Controller																																																										
K	2009	Avalanche	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2009	Avalanche	Body	Body Control Module (aux.)																																																										
K	2009	Avalanche	Body	Digital Radio Receiver																																																										
K	2009	Avalanche	Body	Driver Door Switch																																																										
K	2009	Avalanche	Body	HVAC Control Module Auto																												V	V																														
K	2009	Avalanche	Body	HVAC Control Module Manual																													V																														
K	2009	Avalanche	Body	Instrument Panel Cluster																																																										
K	2009	Avalanche	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																					
K	2009	Avalanche	Body	Park Assist Module																																							V	V	V																	
K	2009	Avalanche	Body	Passenger Door Switch																																																										
K	2009	Avalanche	Body	Passenger Presence System																																										V																
K	2009	Avalanche	Body	Radio																																																										
K	2009	Avalanche	Body	Rear Heated Seat Module																																	V				V																					
K	2009	Avalanche	Body	Rear HVAC/RSA																																																										
K	2009	Avalanche	Body	Rollover Sensor																																																										
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																										V									V						
K	2009	Avalanche	Body	Theft Deterrent Module																																																										
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																							
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																															
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V			V																																																							
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module											V																																															
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																												
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																											
K	2009	Cheyenne	Body	Amplifier (Bose)																																																											
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2009	Cheyenne	Body	Digital Radio Receiver																																																											
K	2009	Cheyenne	Body	Driver Door Switch																																																											
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2009	Cheyenne	Body	Park Assist Module																																							V	V	V																	
K	2009	Cheyenne	Body	Passenger Door Switch																																																											
K	2009	Cheyenne	Body	Passenger Presence System																																										V																
K	2009	Cheyenne	Body	Rear Heated Seat Module																																	V				V																					
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2009	Cheyenne	Body	Rollover Sensor																																																											
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																										V									V						
K	2009	Cheyenne	Body	Theft Deterrent Module																																																											
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																																
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																										
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																																
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																							
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																																
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module		V																																																									
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																							
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module											V																																																
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																									
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																							
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																																
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module		V																																																									
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																							
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																									
K	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																												
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW														V																																													
K	2009	Suburban	Chassis	Electronic Suspension Control																																																												
K	2009	Suburban	Chassis	Trailer Brake Control Module																																																												
K	2009	Suburban	Body	Amplifier (Bose)																																																												
K	2009	Suburban	Body	Assist Step Controller																																																												
K	2009	Suburban	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
K	2009	Suburban	Body	Body Control Module (aux.)																																																											
K	2009	Suburban	Body	Digital Radio Receiver																																																											
K	2009	Suburban	Body	Driver Door Switch																																																											
K	2009	Suburban	Body	HVAC Control Module Auto																												V	V																														
K	2009	Suburban	Body	HVAC Control Module Manual																													V																														
K	2009	Suburban	Body	Instrument Panel Cluster																																																											
K	2009	Suburban	Body	Left Side Object Detection Module																																								V					V													
K	2009	Suburban	Body	Lift Gate Module																																																											
K	2009	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2009	Suburban	Body	Park Assist Module																																							V	V	V																	
K	2009	Suburban	Body	Passenger Door Switch																																																											
K	2009	Suburban	Body	Passenger Presence System																																										V																
K	2009	Suburban	Body	Radio																																																										
K	2009	Suburban	Body	Rear Heated Seat Module																																	V				V																					
K	2009	Suburban	Body	Rear HVAC/RSA																																																											
K	2009	Suburban	Body	Right Side Object Detection Module																																								V					V													
K	2009	Suburban	Body	Rollover Sensor																																																											
K	2009	Suburban	Body	Supplemental Inflatable Restraint																																									V										V						
K	2009	Suburban	Body	Theft Deterrent Module																																																											
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V																																																							
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																																
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																							
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module											V																																																
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																															
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed		V																																																								
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																															
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																						
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																															
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed		V																																																								
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V			V																																																						
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module											V																																															
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module		V																																																								
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																						
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																															
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module		V																																																								
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic	V			V																																																						
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V			V																																																						
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module											V																																															
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																								
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																						
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																																
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																									
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module											V																																																
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																								
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES														V																																												
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2009	Silverado	Chassis	Electronic Suspension Control																																																											
K	2009	Silverado	Chassis	Trailer Brake Control Module																																																											
K	2009	Silverado	Body	Amplifier (Bose)																																																											
K	2009	Silverado	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2009	Silverado	Body	Body Control Module (aux.)																																																											
K	2009	Silverado	Body	Digital Radio Receiver																																																											
K	2009	Silverado	Body	Driver Door Switch																																																											
K	2009	Silverado	Body	HVAC Control Module Auto																												V	V																														
K	2009	Silverado	Body	HVAC Control Module Manual																													V																														
K	2009	Silverado	Body	Instrument Panel Cluster																																																										
K	2009	Silverado	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2009	Silverado	Body	Park Assist Module																																							V	V	V																	
K	2009	Silverado	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2009	Silverado	Body	Passenger Presence System																																										V														
K	2009	Silverado	Body	Radio																																																							
K	2009	Silverado	Body	Rear Heated Seat Module																																	V				V																			
K	2009	Silverado	Body	Rear HVAC/RSA																																																							
K	2009	Silverado	Body	Rollover Sensor																																																							
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																										V									V					
K	2009	Silverado	Body	Theft Deterrent Module																																																							
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																				
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																							
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																							
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																	
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																							
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																							
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																					
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module											V																																													
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																								
K	2009	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																								
K	2009	Silverado Hybrid	Body	Driver Door Switch																																																								
K	2009	Silverado Hybrid	Body	HVAC Control Module																												V	V																												
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
K	2009	Silverado Hybrid	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																			
K	2009	Silverado Hybrid	Body	Park Assist Module																																						V	V	V																
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																																								
K	2009	Silverado Hybrid	Body	Passenger Presence System																																									V															
K	2009	Silverado Hybrid	Body	Radio																																																								
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																	V				V																			
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																								
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																									V									V					
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																								
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																				
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module											V																																													
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																				
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																													
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed		V																																																						
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																				
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																													

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																							
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																					
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																														
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																									
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed		V																																																							
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																					
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																														
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
K	2009	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2009	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2009	Tahoe	Body	Amplifier (Bose)																																																										
K	2009	Tahoe	Body	Assist Step Controller																																																										
K	2009	Tahoe	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2009	Tahoe	Body	Body Control Module (aux.)																																																										
K	2009	Tahoe	Body	Digital Radio Receiver																																																										
K	2009	Tahoe	Body	Driver Door Switch																																																										
K	2009	Tahoe	Body	HVAC Control Module Auto																												V	V																														
K	2009	Tahoe	Body	HVAC Control Module Manual																													V																														
K	2009	Tahoe	Body	Instrument Panel Cluster																																																										
K	2009	Tahoe	Body	Left Side Object Detection Module																																								V					V													
K	2009	Tahoe	Body	Lift Gate Module																																																										
K	2009	Tahoe	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2009	Tahoe	Body	Park Assist Module																																						V	V	V																		
K	2009	Tahoe	Body	Passenger Door Switch																																																										
K	2009	Tahoe	Body	Passenger Presence System																																									V																	
K	2009	Tahoe	Body	Radio																																																									
K	2009	Tahoe	Body	Rear Heated Seat Module																																	V				V																					
K	2009	Tahoe	Body	Rear HVAC/RSA																																																										
K	2009	Tahoe	Body	Right Side Object Detection Module																																								V					V													
K	2009	Tahoe	Body	Rollover Sensor																																																										
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																																									V										V					
K	2009	Tahoe	Body	Theft Deterrent Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																						
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																			
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module											V																																															
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																																											
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																	V				V																					
K	2009	Tahoe Hybrid	Body	HVAC Control Module																												V	V																													
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																							V				V														
K	2009	Tahoe Hybrid	Body	Park Assist Module																																						V	V	V																	
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																									V																	
K	2009	Tahoe Hybrid	Body	Radio																																																										
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																	V				V																					
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																							V				V														
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																										
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																									V									V						
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																															
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																															
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																							
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed											V																																															
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed											V																																															
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
K	2010	Avalanche	Chassis	Electronic Brake Control Module																																																											
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Avalanche	Body	Amplifier (Bose)																																																											
K	2010	Avalanche	Body	Assist Step Controller																																																											
K	2010	Avalanche	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
K	2010	Avalanche	Body	Body Control Module (aux.)																																																											
K	2010	Avalanche	Body	Digital Radio Receiver																																																											
K	2010	Avalanche	Body	Driver Door Switch																																																											
K	2010	Avalanche	Body	HVAC Control Module Auto																												V	V																														
K	2010	Avalanche	Body	HVAC Control Module Manual																													V																														
K	2010	Avalanche	Body	Instrument Panel Cluster																																																											
K	2010	Avalanche	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2010	Avalanche	Body	Park Assist Module																																						V	V	V																	
K	2010	Avalanche	Body	Passenger Door Switch																																																											
K	2010	Avalanche	Body	Passenger Presence System																																									V																	
K	2010	Avalanche	Body	Radio																																																										
K	2010	Avalanche	Body	Rear Heated Seat Module																																	V				V																					
K	2010	Avalanche	Body	Rear HVAC/RSA																																																											
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2010	Avalanche	Body	Theft Deterrent Module																																																											
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																															
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																																
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																											
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																												
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Cheyenne	Body	Amplifier (Bose)																																																											
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2010	Cheyenne	Body	Digital Radio Receiver																																																											
K	2010	Cheyenne	Body	Driver Door Switch																																																											
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2010	Cheyenne	Body	Park Assist Module																																							V	V	V																		
K	2010	Cheyenne	Body	Passenger Door Switch																																																											
K	2010	Cheyenne	Body	Passenger Presence System																																										V																	
K	2010	Cheyenne	Body	Rear Heated Seat Module																																	V				V																					
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
K	2010	Cheyenne	Body	Theft Deterrent Module																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																																
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																																
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed											V																																																
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed											V																																																
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																								
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																																
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																								
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed											V																																																
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed											V																																																
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																									
K	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																												
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW														V																																													
K	2010	Suburban	Chassis	Electronic Suspension Control																																																												
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Suburban	Body	Amplifier (Bose)																																																												
K	2010	Suburban	Body	Assist Step Controller																																																												
K	2010	Suburban	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2010	Suburban	Body	Body Control Module (aux.)																																																												
K	2010	Suburban	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2010	Suburban	Body	Driver Door Switch																																																											
K	2010	Suburban	Body	HVAC Control Module Auto																												V	V																														
K	2010	Suburban	Body	HVAC Control Module Manual																													V																														
K	2010	Suburban	Body	Instrument Panel Cluster																																																										
K	2010	Suburban	Body	Left Side Object Detection Module																																								V				V														
K	2010	Suburban	Body	Lift Gate Module																																																										
K	2010	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2010	Suburban	Body	Park Assist Module																																							V	V	V																	
K	2010	Suburban	Body	Passenger Door Switch																																																										
K	2010	Suburban	Body	Passenger Presence System																																									V																	
K	2010	Suburban	Body	Radio																																																									
K	2010	Suburban	Body	Rear Heated Seat Module																																	V				V																					
K	2010	Suburban	Body	Rear HVAC/RSA																																																										
K	2010	Suburban	Body	Right Side Object Detection Module																																								V				V														
K	2010	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2010	Suburban	Body	Theft Deterrent Module																																																										
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V			V																																																							
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V			V																																																							
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																																
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module											V																																																
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																																
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																																
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																																
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic	V			V																																																							
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V			V																																																							
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module											V																																																
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																									
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																																
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																									
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module											V																																																
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																								
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES														V																																													

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2010	Silverado	Chassis	Electronic Suspension Control																																																										
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2010	Silverado	Body	Amplifier (Bose)																																																										
K	2010	Silverado	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2010	Silverado	Body	Body Control Module (aux.)																																																										
K	2010	Silverado	Body	Digital Radio Receiver																																																										
K	2010	Silverado	Body	Driver Door Switch																																																										
K	2010	Silverado	Body	HVAC Control Module Auto																												V	V																													
K	2010	Silverado	Body	HVAC Control Module Manual																													V																													
K	2010	Silverado	Body	Instrument Panel Cluster																																																										
K	2010	Silverado	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																				
K	2010	Silverado	Body	Park Assist Module																																							V	V	V																	
K	2010	Silverado	Body	Passenger Door Switch																																																										
K	2010	Silverado	Body	Passenger Presence System																																										V																
K	2010	Silverado	Body	Radio																																																										
K	2010	Silverado	Body	Rear Heated Seat Module																																	V				V																					
K	2010	Silverado	Body	Rear HVAC/RSA																																																										
K	2010	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2010	Silverado	Body	Theft Deterrent Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																						
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																			
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module										V																																																
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2010	Silverado Hybrid	Body	Heated Seat Module																																	V				V																					
K	2010	Silverado Hybrid	Body	HVAC Control Module																												V	V																													
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Silverado Hybrid	Body	Park Assist Module																																							V	V	V																	
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2010	Silverado Hybrid	Body	Passenger Presence System																																										V																
K	2010	Silverado Hybrid	Body	Radio																																																										
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																	V				V																					
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																											
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																																
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																																
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed											V																																																
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed											V																																																
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
K	2010	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Tahoe	Body	Amplifier (Bose)																																																												
K	2010	Tahoe	Body	Assist Step Controller																																																												
K	2010	Tahoe	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																	
K	2010	Tahoe	Body	Body Control Module (aux.)																																																												
K	2010	Tahoe	Body	Digital Radio Receiver																																																												
K	2010	Tahoe	Body	Driver Door Switch																																																												
K	2010	Tahoe	Body	HVAC Control Module Auto																												V	V																															
K	2010	Tahoe	Body	HVAC Control Module Manual																													V																															
K	2010	Tahoe	Body	Instrument Panel Cluster																																																											
K	2010	Tahoe	Body	Left Side Object Detection Module																																								V					V													
K	2010	Tahoe	Body	Lift Gate Module																																																											
K	2010	Tahoe	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2010	Tahoe	Body	Park Assist Module																																						V	V	V																	
K	2010	Tahoe	Body	Passenger Door Switch																																																											
K	2010	Tahoe	Body	Passenger Presence System																																										V															
K	2010	Tahoe	Body	Radio																																																										
K	2010	Tahoe	Body	Rear Heated Seat Module																																	V				V																					
K	2010	Tahoe	Body	Rear HVAC/RSA																																																											
K	2010	Tahoe	Body	Right Side Object Detection Module																																								V					V													
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																											
K	2010	Tahoe	Body	Theft Deterrent Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																					
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																									
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module											V																																																
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																	

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																	V				V																					
K	2010	Tahoe Hybrid	Body	HVAC Control Module																											V	V																														
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																							V					V													
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2010	Tahoe Hybrid	Body	Park Assist Module																																							V	V	V																	
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																									V																	
K	2010	Tahoe Hybrid	Body	Radio																																																										
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																	V				V																					
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																							V					V													
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed											V																																															
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed											V																																															
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module	V			V																																																						
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module	V			V																																																						
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																															
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																															
K	2011	Avalanche	Chassis	Electronic Brake Control Module																																																											
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Avalanche	Body	Amplifier (Bose)																																																											
K	2011	Avalanche	Body	Assist Step Controller																																																											
K	2011	Avalanche	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2011	Avalanche	Body	Body Control Module (aux.)																																																											
K	2011	Avalanche	Body	Digital Radio Receiver																																																											
K	2011	Avalanche	Body	Driver Door Switch																																																											
K	2011	Avalanche	Body	HVAC Control Module Auto																												V	V																														
K	2011	Avalanche	Body	HVAC Control Module Manual																													V																														
K	2011	Avalanche	Body	Instrument Panel Cluster																																																											
K	2011	Avalanche	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2011	Avalanche	Body	Park Assist Module																																							V	V	V																	
K	2011	Avalanche	Body	Passenger Door Switch																																																											
K	2011	Avalanche	Body	Passenger Presence System																																									V																	
K	2011	Avalanche	Body	Radio																																																										
K	2011	Avalanche	Body	Rear Heated Seat Module																																	V				V																					
K	2011	Avalanche	Body	Rear HVAC/RSA																																																											
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2011	Avalanche	Body	Theft Deterrent Module																																																											
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																															
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																															
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																											
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Cheyenne	Body	Amplifier (Bose)																																																										
K	2011	Cheyenne	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2011	Cheyenne	Body	Digital Radio Receiver																																																										
K	2011	Cheyenne	Body	Driver Door Switch																																																										
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2011	Cheyenne	Body	Park Assist Module																																							V	V	V																		
K	2011	Cheyenne	Body	Passenger Door Switch																																																										
K	2011	Cheyenne	Body	Passenger Presence System																																									V																	
K	2011	Cheyenne	Body	Rear Heated Seat Module																																	V				V																				
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2011	Cheyenne	Body	Theft Deterrent Module																																																										
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																																
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																																
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed											V																																																
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed											V																																																
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																								
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																																
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																										
K	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																											
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW														V																																												
K	2011	Suburban	Chassis	Electronic Suspension Control																																																											
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Suburban	Body	Amplifier (Bose)																																																											
K	2011	Suburban	Body	Assist Step Controller																																																											
K	2011	Suburban	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2011	Suburban	Body	Body Control Module (aux.)																																																											
K	2011	Suburban	Body	Digital Radio Receiver																																																											
K	2011	Suburban	Body	Driver Door Switch																																																											
K	2011	Suburban	Body	HVAC Control Module Auto																												V	V																														
K	2011	Suburban	Body	HVAC Control Module Manual																													V																														

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2011	Suburban	Body	Instrument Panel Cluster																																																									
K	2011	Suburban	Body	Left Side Object Detection Module																																							V					V												
K	2011	Suburban	Body	Lift Gate Module																																																							
K	2011	Suburban	Body	Memory Seat Module																													V	V	V	V	V	V	V	V																				
K	2011	Suburban	Body	Park Assist Module																																					V	V	V																
K	2011	Suburban	Body	Passenger Door Switch																																																							
K	2011	Suburban	Body	Passenger Presence System																																								V															
K	2011	Suburban	Body	Radio																																																							
K	2011	Suburban	Body	Rear Heated Seat Module																																V				V																			
K	2011	Suburban	Body	Rear HVAC/RSA																																																							
K	2011	Suburban	Body	Right Side Object Detection Module																																							V					V												
K	2011	Suburban	Body	Supplemental Inflatable Restraint																																																							
K	2011	Suburban	Body	Theft Deterrent Module																																																							
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V			V																																																				
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V			V																																																				
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																													
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																				
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module											V																																													
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module	V			V																																																			
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module	V			V																																																			
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																													
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																						
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																				
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																													
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																						
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic	V			V																																																				
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual	V			V																																																				
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																													
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																						
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																				
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																													
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																						
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module											V																																													
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module			V																																																				
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																								
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module											V																																													
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module			V																																																				
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES														V																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2011	Silverado	Chassis	Electronic Suspension Control																																																										
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2011	Silverado	Body	Amplifier (Bose)																																																										
K	2011	Silverado	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2011	Silverado	Body	Body Control Module (aux.)																																																										
K	2011	Silverado	Body	Digital Radio Receiver																																																										
K	2011	Silverado	Body	Driver Door Switch																																																										
K	2011	Silverado	Body	HVAC Control Module Auto																												V	V																													
K	2011	Silverado	Body	HVAC Control Module Manual																													V																													
K	2011	Silverado	Body	Instrument Panel Cluster																																																										
K	2011	Silverado	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																				
K	2011	Silverado	Body	Park Assist Module																																							V	V	V																	
K	2011	Silverado	Body	Passenger Door Switch																																																										
K	2011	Silverado	Body	Passenger Presence System																																										V																
K	2011	Silverado	Body	Radio																																																										
K	2011	Silverado	Body	Rear Heated Seat Module																																	V				V																					
K	2011	Silverado	Body	Rear HVAC/RSA																																																										
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2011	Silverado	Body	Theft Deterrent Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																						
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																			
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module										V																																																
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2011	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2011	Silverado Hybrid	Body	Heated Seat Module																																	V				V																					
K	2011	Silverado Hybrid	Body	HVAC Control Module																												V	V																													
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2011	Silverado Hybrid	Body	Park Assist Module																																							V	V	V																	
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2011	Silverado Hybrid	Body	Passenger Presence System																																										V																
K	2011	Silverado Hybrid	Body	Radio																																																										
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																	V				V																					
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																															
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																															
K	2011	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Tahoe	Body	Amplifier (Bose)																																																										
K	2011	Tahoe	Body	Assist Step Controller																																																										
K	2011	Tahoe	Body	Body Control Module														V	V	V	V	V		V		V	V			V																																
K	2011	Tahoe	Body	Body Control Module (aux.)																																																										
K	2011	Tahoe	Body	Digital Radio Receiver																																																										
K	2011	Tahoe	Body	Driver Door Switch																																																										
K	2011	Tahoe	Body	HVAC Control Module Auto																											V	V																														
K	2011	Tahoe	Body	HVAC Control Module Manual																												V																														
K	2011	Tahoe	Body	Instrument Panel Cluster																																																										
K	2011	Tahoe	Body	Left Side Object Detection Module																																							V				V															
K	2011	Tahoe	Body	Lift Gate Module																																																										
K	2011	Tahoe	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2011	Tahoe	Body	Park Assist Module																																							V	V	V																	
K	2011	Tahoe	Body	Passenger Door Switch																																																										
K	2011	Tahoe	Body	Passenger Presence System																																										V																
K	2011	Tahoe	Body	Radio																																																										
K	2011	Tahoe	Body	Rear Heated Seat Module																																	V				V																					
K	2011	Tahoe	Body	Rear HVAC/RSA																																																										
K	2011	Tahoe	Body	Right Side Object Detection Module																																							V				V															
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2011	Tahoe	Body	Theft Deterrent Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																						
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																			
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																								
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module											V																																															
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2011	Tahoe Hybrid	Body	Body Control Module														V	V	V	V	V		V		V	V			V																																
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																	V				V																					
K	2011	Tahoe Hybrid	Body	HVAC Control Module																												V	V																													

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																							V					V													
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																																									
K	2011	Tahoe Hybrid	Body	Park Assist Module																																						V	V	V																	
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																									
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																									V																
K	2011	Tahoe Hybrid	Body	Radio																																																									
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																	V				V																				
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																							V					V													
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																									
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																						
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																								
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed											V																																															
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed											V																																															
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																															
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																															
K	2012	Avalanche	Chassis	Electronic Brake Control Module														V																																												
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Avalanche	Body	Amplifier (Bose)																																																											
K	2012	Avalanche	Body	Assist Step Controller																																																											
K	2012	Avalanche	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2012	Avalanche	Body	Body Control Module (aux.)																																																											
K	2012	Avalanche	Body	Digital Radio Receiver																																																											
K	2012	Avalanche	Body	Driver Door Switch																																																											
K	2012	Avalanche	Body	HVAC Control Module Auto																												V	V																														
K	2012	Avalanche	Body	HVAC Control Module Manual																													V																														
K	2012	Avalanche	Body	Instrument Panel Cluster																																																											
K	2012	Avalanche	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2012	Avalanche	Body	Navigation Radio																																																											
K	2012	Avalanche	Body	Park Assist Module																																						V	V	V																		
K	2012	Avalanche	Body	Passenger Door Switch																																																											
K	2012	Avalanche	Body	Passenger Presence System																																									V																
K	2012	Avalanche	Body	Radio																																																										
K	2012	Avalanche	Body	Rear Heated Seat Module																																	V				V																				
K	2012	Avalanche	Body	Rear HVAC/RSA																																																											
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2012	Avalanche	Body	Theft Deterrent Module																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V			V																																																						
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V			V																																																						
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																															

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																						
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module											V																																															
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																								
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES														V																																												
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES														V																																												
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																												
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																											
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Cheyenne	Body	Amplifier (Bose)																																																											
K	2012	Cheyenne	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2012	Cheyenne	Body	Digital Radio Receiver																																																											
K	2012	Cheyenne	Body	Driver Door Switch																																																											
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2012	Cheyenne	Body	Park Assist Module																																							V	V	V																		
K	2012	Cheyenne	Body	Passenger Door Switch																																																											
K	2012	Cheyenne	Body	Passenger Presence System																																										V																	
K	2012	Cheyenne	Body	Rear Heated Seat Module																																	V				V																					
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
K	2012	Cheyenne	Body	Theft Deterrent Module																																																											
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																																
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																																
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																								
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed											V																																																
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed											V																																																
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																									
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																								
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																																
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																										
K	2012	Suburban	Chassis	EBCM Under 8600 GVW														V																																													
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW														V																																													
K	2012	Suburban	Chassis	Electronic Suspension Control																																																											
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Suburban	Body	Amplifier (Bose)																																																											
K	2012	Suburban	Body	Assist Step Controller																																																											
K	2012	Suburban	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
K	2012	Suburban	Body	Body Control Module (aux.)																																																											
K	2012	Suburban	Body	Digital Radio Receiver																																																											
K	2012	Suburban	Body	Driver Door Switch																																																											
K	2012	Suburban	Body	HVAC Control Module Auto																												V	V																														
K	2012	Suburban	Body	HVAC Control Module Manual																													V																														
K	2012	Suburban	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2012	Suburban	Body	Left Side Object Detection Module																																								V					V												
K	2012	Suburban	Body	Lift Gate Module																																																								
K	2012	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
K	2012	Suburban	Body	Navigation Radio																																																								
K	2012	Suburban	Body	Park Assist Module																																						V	V	V																	
K	2012	Suburban	Body	Passenger Door Switch																																																								
K	2012	Suburban	Body	Passenger Presence System																																									V															
K	2012	Suburban	Body	Radio																																																								
K	2012	Suburban	Body	Rear Heated Seat Module																																	V				V																				
K	2012	Suburban	Body	Rear HVAC/RSA																																																								
K	2012	Suburban	Body	Right Side Object Detection Module																																								V					V												
K	2012	Suburban	Body	Supplemental Inflatable Restraint																																																								
K	2012	Suburban	Body	Theft Deterrent Module																																																								
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V			V																																																					
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V			V																																																					
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																														
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																					
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module											V																																														
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																					
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																														
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																							
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																					
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module											V																																														
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																							
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic	V			V																																																					
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual	V			V																																																					
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																														
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																							
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																					
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																														
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																							
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																									
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																									
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																									
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module											V																																														
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module			V																																																						
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																									
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module											V																																														
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module			V																																																						
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES														V																																										
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES														V																																										
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES														V																																										
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2012	Silverado	Chassis	Electronic Suspension Control																																																										
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2012	Silverado	Body	Amplifier (Bose)																																																										
K	2012	Silverado	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2012	Silverado	Body	Body Control Module (aux.)																																																										
K	2012	Silverado	Body	Digital Radio Receiver																																																										
K	2012	Silverado	Body	Driver Door Switch																																																										
K	2012	Silverado	Body	HVAC Control Module Auto																												V	V																													
K	2012	Silverado	Body	HVAC Control Module Manual																													V																													
K	2012	Silverado	Body	Instrument Panel Cluster																																																										
K	2012	Silverado	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																				
K	2012	Silverado	Body	Navigation Radio																																																										
K	2012	Silverado	Body	Park Assist Module																																							V	V	V																	
K	2012	Silverado	Body	Passenger Door Switch																																																										
K	2012	Silverado	Body	Passenger Presence System																																										V																
K	2012	Silverado	Body	Radio																																																										
K	2012	Silverado	Body	Rear Heated Seat Module																																	V				V																					
K	2012	Silverado	Body	Rear HVAC/RSA																																																										
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2012	Silverado	Body	Theft Deterrent Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																						
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																			
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module										V																																																
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2012	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2012	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2012	Silverado Hybrid	Body	Heated Seat Module																																	V				V																					
K	2012	Silverado Hybrid	Body	HVAC Control Module																												V	V																													
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2012	Silverado Hybrid	Body	Navigation Radio																																																										
K	2012	Silverado Hybrid	Body	Park Assist Module																																							V	V	V																	
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2012	Silverado Hybrid	Body	Passenger Presence System																																										V																
K	2012	Silverado Hybrid	Body	Radio																																																										
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																	V				V																					
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																															
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																															
K	2012	Tahoe	Chassis	EBCM with Trailer Brake														V																																												
K	2012	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Tahoe	Body	Amplifier (Bose)																																																										
K	2012	Tahoe	Body	Assist Step Controller																																																										
K	2012	Tahoe	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2012	Tahoe	Body	Body Control Module (aux.)																																																										
K	2012	Tahoe	Body	Digital Radio Receiver																																																										
K	2012	Tahoe	Body	Driver Door Switch																																																										
K	2012	Tahoe	Body	HVAC Control Module Auto																												V	V																													
K	2012	Tahoe	Body	HVAC Control Module Manual																													V																													
K	2012	Tahoe	Body	Instrument Panel Cluster																																																										
K	2012	Tahoe	Body	Left Side Object Detection Module																																							V				V															
K	2012	Tahoe	Body	Lift Gate Module																																																										
K	2012	Tahoe	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2012	Tahoe	Body	Navigation Radio																																																										
K	2012	Tahoe	Body	Park Assist Module																																							V	V	V																	
K	2012	Tahoe	Body	Passenger Door Switch																																																										
K	2012	Tahoe	Body	Passenger Presence System																																										V																
K	2012	Tahoe	Body	Radio																																																										
K	2012	Tahoe	Body	Rear Heated Seat Module																																	V				V																					
K	2012	Tahoe	Body	Rear HVAC/RSA																																																										
K	2012	Tahoe	Body	Right Side Object Detection Module																																							V				V															
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2012	Tahoe	Body	Theft Deterrent Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																						
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																			
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																								
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module											V																																															
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2012	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																	V				V																					

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2012	Tahoe Hybrid	Body	HVAC Control Module																												V	V																											
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																								V					V											
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																																								
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																								
K	2012	Tahoe Hybrid	Body	Park Assist Module																																							V	V	V																
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																								
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																										V															
K	2012	Tahoe Hybrid	Body	Radio																																																								
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																	V				V																				
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																								V					V											
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																					
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																							
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed											V																																														
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed											V																																														
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																					
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																							
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																														
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																														
K	2013	Avalanche	Chassis	Electronic Brake Control Module														V																																											
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Avalanche	Body	Amplifier (Bose)																																																									
K	2013	Avalanche	Body	Assist Step Controller																																																									
K	2013	Avalanche	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
K	2013	Avalanche	Body	Body Control Module (aux.)																																																									
K	2013	Avalanche	Body	Digital Radio Receiver																																																									
K	2013	Avalanche	Body	Driver Door Switch																																																									
K	2013	Avalanche	Body	HVAC Control Module Auto																												V	V																													
K	2013	Avalanche	Body	HVAC Control Module Manual																													V																													
K	2013	Avalanche	Body	Instrument Panel Cluster																																																									
K	2013	Avalanche	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
K	2013	Avalanche	Body	Navigation Radio																																																									
K	2013	Avalanche	Body	Park Assist Module																																							V	V	V																
K	2013	Avalanche	Body	Passenger Door Switch																																																									
K	2013	Avalanche	Body	Passenger Presence System																																										V															
K	2013	Avalanche	Body	Radio																																																									
K	2013	Avalanche	Body	Rear Heated Seat Module																																	V				V																				
K	2013	Avalanche	Body	Rear HVAC/RSA																																																									
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																									
K	2013	Avalanche	Body	Theft Deterrent Module																																																									
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V			V																																																					
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V			V																																																					
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																							
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																									
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module											V																																																
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																																
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES														V																																													
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES														V																																													
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																													
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																												
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Cheyenne	Body	Amplifier (Bose)																																																												
K	2013	Cheyenne	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																												
K	2013	Cheyenne	Body	Digital Radio Receiver																																																												
K	2013	Cheyenne	Body	Driver Door Switch																																																												
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																												
K	2013	Cheyenne	Body	Park Assist Module																																							V	V	V																			
K	2013	Cheyenne	Body	Passenger Door Switch																																																												
K	2013	Cheyenne	Body	Passenger Presence System																																										V																		
K	2013	Cheyenne	Body	Rear Heated Seat Module																																	V				V																						
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																												
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																												
K	2013	Cheyenne	Body	Theft Deterrent Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																								
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed											V																																																	
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed											V																																																	
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																																	
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																																	
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed	V			V																																																								
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																																	
K	2013	Suburban	Chassis	EBCM Under 8600 GVW														V																																													
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW														V																																													
K	2013	Suburban	Chassis	Electronic Suspension Control																																																												
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Suburban	Body	Amplifier (Bose)																																																												
K	2013	Suburban	Body	Assist Step Controller																																																												
K	2013	Suburban	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
K	2013	Suburban	Body	Body Control Module (aux.)																																																												
K	2013	Suburban	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2013	Suburban	Body	Driver Door Switch																																																										
K	2013	Suburban	Body	HVAC Control Module Auto																												V	V																													
K	2013	Suburban	Body	HVAC Control Module Manual																													V																														
K	2013	Suburban	Body	Instrument Panel Cluster																																																										
K	2013	Suburban	Body	Left Side Object Detection Module																																							V					V														
K	2013	Suburban	Body	Lift Gate Module																																																										
K	2013	Suburban	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2013	Suburban	Body	Navigation Radio																																																									
K	2013	Suburban	Body	Park Assist Module																																						V	V	V																		
K	2013	Suburban	Body	Passenger Door Switch																																																									
K	2013	Suburban	Body	Passenger Presence System																																									V																
K	2013	Suburban	Body	Radio																																																									
K	2013	Suburban	Body	Rear Heated Seat Module																																	V				V																					
K	2013	Suburban	Body	Rear HVAC/RSA																																																									
K	2013	Suburban	Body	Right Side Object Detection Module																																							V					V														
K	2013	Suburban	Body	Supplemental Inflatable Restraint																																																									
K	2013	Suburban	Body	Theft Deterrent Module																																																									
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic	V			V																																																						
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual	V			V																																																						
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																															
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module											V																																															
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																						
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																								
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module											V																																															
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																															
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic	V			V																																																						
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual	V			V																																																						
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																															
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module											V																																															
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																						
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																															
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module			V																																																							
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module											V																																															
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES														V																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES														V																																												
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES														V																																												
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2013	Silverado	Chassis	Electronic Suspension Control																																																											
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
K	2013	Silverado	Body	Amplifier (Bose)																																																											
K	2013	Silverado	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
K	2013	Silverado	Body	Body Control Module (aux.)																																																											
K	2013	Silverado	Body	Digital Radio Receiver																																																											
K	2013	Silverado	Body	Driver Door Switch																																																											
K	2013	Silverado	Body	HVAC Control Module Auto																												V	V																															
K	2013	Silverado	Body	HVAC Control Module Manual																													V																															
K	2013	Silverado	Body	Instrument Panel Cluster																																																											
K	2013	Silverado	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																						
K	2013	Silverado	Body	Navigation Radio																																																											
K	2013	Silverado	Body	Park Assist Module																																							V	V	V																			
K	2013	Silverado	Body	Passenger Door Switch																																																											
K	2013	Silverado	Body	Passenger Presence System																																										V																	
K	2013	Silverado	Body	Radio																																																											
K	2013	Silverado	Body	Rear Heated Seat Module																																	V				V																						
K	2013	Silverado	Body	Rear HVAC/RSA																																																											
K	2013	Silverado	Body	Supplemental Inflatable Restraint																																																											
K	2013	Silverado	Body	Theft Deterrent Module																																																											
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																							
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																					
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module										V																																																	
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2013	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2013	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2013	Silverado Hybrid	Body	Heated Seat Module																																	V				V																						
K	2013	Silverado Hybrid	Body	HVAC Control Module																												V	V																															
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2013	Silverado Hybrid	Body	Navigation Radio																																																												
K	2013	Silverado Hybrid	Body	Park Assist Module																																							V	V	V																			
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2013	Silverado Hybrid	Body	Passenger Presence System																																										V																	

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2013	Silverado Hybrid	Body	Radio																																																											
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																		V				V																					
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																																	
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																																	
K	2013	Tahoe	Chassis	Electronic Brake Control Module														V																																														
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Tahoe	Body	Amplifier (Bose)																																																												
K	2013	Tahoe	Body	Assist Step Controller																																																												
K	2013	Tahoe	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																	
K	2013	Tahoe	Body	Body Control Module (aux.)																																																												
K	2013	Tahoe	Body	Digital Radio Receiver																																																												
K	2013	Tahoe	Body	Driver Door Switch																																																												
K	2013	Tahoe	Body	HVAC Control Module Auto																												V	V																															
K	2013	Tahoe	Body	HVAC Control Module Manual																													V																															
K	2013	Tahoe	Body	Instrument Panel Cluster																																																												
K	2013	Tahoe	Body	Left Side Object Detection Module																																								V				V																
K	2013	Tahoe	Body	Lift Gate Module																																																												
K	2013	Tahoe	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																							
K	2013	Tahoe	Body	Navigation Radio																																																												
K	2013	Tahoe	Body	Park Assist Module																																								V	V	V																		
K	2013	Tahoe	Body	Passenger Door Switch																																																												
K	2013	Tahoe	Body	Passenger Presence System																																												V																
K	2013	Tahoe	Body	Radio																																																												
K	2013	Tahoe	Body	Rear Heated Seat Module																																		V				V																						
K	2013	Tahoe	Body	Rear HVAC/RSA																																																												
K	2013	Tahoe	Body	Right Side Object Detection Module																																								V				V																
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2013	Tahoe	Body	Theft Deterrent Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																					
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module											V																																																	
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
K	2013	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																											
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																	V				V																						
K	2013	Tahoe Hybrid	Body	HVAC Control Module																												V	V																														
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																							V					V														
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																																											
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																												
K	2013	Tahoe Hybrid	Body	Park Assist Module																																						V	V	V																			
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																									V																		
K	2013	Tahoe Hybrid	Body	Radio																																																											
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																	V				V																						
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																												V				V										
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																												
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																												
K	2014	Cheyenne	Chassis	Power Steering Control Module																																																												
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2014	Cheyenne	Body	Body Control Module																																																												
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Cheyenne	Body	Passenger Presence Module																																																												
K	2014	Cheyenne	Body	Instrument Cluster																																																												
K	2014	Cheyenne	Body	Radio Control																																																												
K	2014	Cheyenne	Body	HVAC Control																																																												
K	2014	Cheyenne	Body	Radio																																																											
K	2014	Cheyenne	Body	Amplifier																																																											
K	2014	Cheyenne	Body	Media Disc Player																																																												
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																												
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2014	Cheyenne	Body	HVAC Control Module																																																										
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																										
K	2014	Cheyenne	Body	Parking Assist Control Module																																																										
K	2014	Cheyenne	Body	Frontview Camera Module																																																										
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2014	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2014	Silverado	Chassis	Parking Brake Control Module																																																										
K	2014	Silverado	Chassis	Power Steering Control Module																																																										
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Silverado	Body	Body Control Module																																																										
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Silverado	Body	Passenger Presence Module																																																										
K	2014	Silverado	Body	Instrument Cluster																																																										
K	2014	Silverado	Body	Radio Control																																																										
K	2014	Silverado	Body	HVAC Control																																																										
K	2014	Silverado	Body	Radio																																																										
K	2014	Silverado	Body	Amplifier																																																										
K	2014	Silverado	Body	Media Disc Player																																																										
K	2014	Silverado	Body	Human Machine Interface Control Module																																																										
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2014	Silverado	Body	Parking Assist Control Module																																																										
K	2014	Silverado	Body	Frontview Camera Module																																																										
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																										
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																										
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2014	Silverado HD	Chassis	Suspension Control Module																																																										
K	2014	Silverado HD	Body	Body Control Module																																																										
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Silverado HD	Body	Passenger Presence Module																																																										
K	2014	Silverado HD	Body	Instrument Cluster																																																										
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
K	2014	Silverado HD	Body	Base Radio																																																										
K	2014	Silverado HD	Body	Navigation Radio																																																										
K	2014	Silverado HD	Body	Uplevel Radio																																																										
K	2014	Silverado HD	Body	Amplifier																																																										
K	2014	Silverado HD	Body	Rear Audio Control Module																																																										
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																										
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																										
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Silverado HD	Body	Seat Memory Control Module																																																										
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																										
K	2014	Silverado HD	Body	Parking Assist Control Module																																																										
K	2014	Silverado HD	Body	Theft Deterrent Module																																																										
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																										
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2014	Suburban	Chassis	Parking Brake Control Module																																																										
K	2014	Suburban	Chassis	Suspension Control Module																																																										
K	2014	Suburban	Body	Body Control Module																																																										
K	2014	Suburban	Body	Auxiliary Body Control Module																																																										
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Suburban	Body	Passenger Presence Module																																																										
K	2014	Suburban	Body	Instrument Cluster																																																										
K	2014	Suburban	Body	Base Radio																																																										
K	2014	Suburban	Body	Navigation Radio																																																										
K	2014	Suburban	Body	Uplevel Radio																																																										
K	2014	Suburban	Body	Amplifier																																																										
K	2014	Suburban	Body	Rear Audio Control Module																																																										
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																										
K	2014	Suburban	Body	Personal Audio Link Control Module																																																										
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Suburban	Body	Liftgate Control Module																																																										
K	2014	Suburban	Body	Seat Memory Control Module																																																										
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																										
K	2014	Suburban	Body	Assist Step Control Module																																																										
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																										
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																										
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																										
K	2014	Suburban	Body	Parking Assist Control Module																																																										
K	2014	Suburban	Body	Theft Deterrent Module																																																										
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																										
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																										
K	2014	Tahoe	Chassis	Suspension Control Module																																																										
K	2014	Tahoe	Body	Body Control Module																																																										
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																										
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Tahoe	Body	Passenger Presence Module																																																										
K	2014	Tahoe	Body	Instrument Cluster																																																										
K	2014	Tahoe	Body	Base Radio																																																										
K	2014	Tahoe	Body	Navigation Radio																																																										
K	2014	Tahoe	Body	Uplevel Radio																																																										
K	2014	Tahoe	Body	Amplifier																																																										
K	2014	Tahoe	Body	Rear Audio Control Module																																																										
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																										
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																										
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Tahoe	Body	Liftgate Control Module																																																										
K	2014	Tahoe	Body	Seat Memory Control Module																																																										
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																										
K	2014	Tahoe	Body	Assist Step Control Module																																																										
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																										
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																										
K	2014	Tahoe	Body	Parking Assist Control Module																																																										
K	2014	Tahoe	Body	Theft Deterrent Module																																																										
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																											
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																											
K	2015	Cheyenne	Chassis	Power Steering Control Module																																																											
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Cheyenne	Chassis	Suspension Control Module																																																											
K	2015	Cheyenne	Body	Body Control Module																																																											
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Cheyenne	Body	Passenger Presence Module																																																											
K	2015	Cheyenne	Body	Instrument Cluster																																																											
K	2015	Cheyenne	Body	Radio Controls																																																											
K	2015	Cheyenne	Body	HVAC Controls																																																											
K	2015	Cheyenne	Body	Radio																																																											
K	2015	Cheyenne	Body	Amplifier																																																											
K	2015	Cheyenne	Body	Media Disc Player																																																											
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																											
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																											
K	2015	Cheyenne	Body	HVAC Control Module																																																											
K	2015	Cheyenne	Body	Parking Assist Control Module																																																											
K	2015	Cheyenne	Body	Frontview Camera Module																																																											
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2015	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																										
K	2015	Silverado	Chassis	Power Steering Control Module																																																										
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Silverado	Chassis	Suspension Control Module																																																										
K	2015	Silverado	Body	Body Control Module																																																										
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Silverado	Body	Passenger Presence Module																																																										
K	2015	Silverado	Body	Instrument Cluster																																																										
K	2015	Silverado	Body	Radio Controls																																																										
K	2015	Silverado	Body	HVAC Controls																																																										
K	2015	Silverado	Body	Radio																																																										
K	2015	Silverado	Body	Amplifier																																																										
K	2015	Silverado	Body	Media Disc Player																																																										
K	2015	Silverado	Body	Human Machine Interface Control Module																																																										
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																																										
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2015	Silverado	Body	Parking Assist Control Module																																																										
K	2015	Silverado	Body	Frontview Camera Module																																																										
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2015	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
K	2015	Suburban	Chassis	Parking Brake Control Module																																																										
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2015	Suburban	Chassis	Power Steering Control Module																																																										
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Suburban	Chassis	Suspension Control Module																																																										
K	2015	Suburban	Body	Body Control Module																																																										
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Suburban	Body	Passenger Presence Module																																																										
K	2015	Suburban	Body	Instrument Cluster																																																										
K	2015	Suburban	Body	Radio Controls																																																										
K	2015	Suburban	Body	HVAC Controls																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2015	Suburban	Body	Radio																																																											
K	2015	Suburban	Body	Amplifier																																																											
K	2015	Suburban	Body	Media Disc Player																																																											
K	2015	Suburban	Body	Human Machine Interface Control Module																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2015	Suburban	Body	HVAC Control Module																																																											
K	2015	Suburban	Body	Liftgate Control Module																																																											
K	2015	Suburban	Body	Keyless Entry Control Module																																																											
K	2015	Suburban	Body	Assist Step Control Module																																																											
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																											
K	2015	Suburban	Body	Parking Assist Control Module																																																											
K	2015	Suburban	Body	Frontview Camera Module																																																											
K	2015	Suburban	Body	Steering Column Lock Control Module																																																											
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																											
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																											
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																											
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																											
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																											
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																											
K	2015	Tahoe	Chassis	Power Steering Control Module																																																											
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Tahoe	Chassis	Suspension Control Module																																																											
K	2015	Tahoe	Body	Body Control Module																																																											
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Tahoe	Body	Passenger Presence Module																																																											
K	2015	Tahoe	Body	Instrument Cluster																																																											
K	2015	Tahoe	Body	Radio Controls																																																											
K	2015	Tahoe	Body	HVAC Controls																																																											
K	2015	Tahoe	Body	Radio																																																											
K	2015	Tahoe	Body	Amplifier																																																											
K	2015	Tahoe	Body	Media Disc Player																																																											
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2015	Tahoe	Body	HVAC Control Module																																																											
K	2015	Tahoe	Body	Liftgate Control Module																																																											
K	2015	Tahoe	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2015	Tahoe	Body	Assist Step Control Module																																																										
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2015	Tahoe	Body	Parking Assist Control Module																																																										
K	2015	Tahoe	Body	Frontview Camera Module																																																										
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																										
K	2015	Tahoe	Body	Battery Energy Control Module																																																										
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																										
K	2016	Cheyenne	Chassis	Power Steering Control Module																																																										
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Cheyenne	Chassis	Suspension Control Module																																																										
K	2016	Cheyenne	Body	Body Control Module																																																										
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Cheyenne	Body	Passenger Presence Module																																																										
K	2016	Cheyenne	Body	Instrument Cluster																																																										
K	2016	Cheyenne	Body	Radio Controls																																																										
K	2016	Cheyenne	Body	HVAC Controls																																																										
K	2016	Cheyenne	Body	Radio																																																										
K	2016	Cheyenne	Body	Amplifier																																																										
K	2016	Cheyenne	Body	Media Disc Player																																																										
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																										
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
K	2016	Cheyenne	Body	HVAC Control Module																																																										
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																										
K	2016	Cheyenne	Body	Parking Assist Control Module																																																										
K	2016	Cheyenne	Body	Frontview Camera Module																																																										
K	2016	Cheyenne	Body	Frontview Camera Module																																																										
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2016	Silverado	Chassis	Power Steering Control Module																																																										
K	2016	Silverado	Chassis	Power Steering Control Module																																																										
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Silverado	Chassis	Suspension Control Module																																																										
K	2016	Silverado	Body	Body Control Module																																																										
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Silverado	Body	Passenger Presence Module																																																										
K	2016	Silverado	Body	Instrument Cluster																																																										
K	2016	Silverado	Body	Radio Controls																																																										
K	2016	Silverado	Body	HVAC Controls																																																										
K	2016	Silverado	Body	Radio (IO3)																																																										
K	2016	Silverado	Body	Radio (IOB)																																																										
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
K	2016	Silverado	Body	Amplifier																																																										
K	2016	Silverado	Body	Media Disc Player																																																										
K	2016	Silverado	Body	Human Machine Interface Control Module																																																										
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																										
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																										
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																										
K	2016	Silverado	Body	Parking Assist Control Module																																																										
K	2016	Silverado	Body	Frontview Camera Module																																																										
K	2016	Silverado	Body	Frontview Camera Module																																																										
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
K	2016	Suburban	Chassis	Parking Brake Control Module																																																										
K	2016	Suburban	Chassis	Power Steering Control Module																																																										
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Suburban	Chassis	Suspension Control Module																																																										
K	2016	Suburban	Body	Body Control Module																																																										
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2016	Suburban	Body	Passenger Presence Module																																																										
K	2016	Suburban	Body	Instrument Cluster																																																										
K	2016	Suburban	Body	Radio Controls																																																										
K	2016	Suburban	Body	HVAC Controls																																																										
K	2016	Suburban	Body	Radio																																																										
K	2016	Suburban	Body	Amplifier																																																										
K	2016	Suburban	Body	Media Disc Player																																																										
K	2016	Suburban	Body	Human Machine Interface Control Module																																																											
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																																											
K	2016	Suburban	Body	HVAC Control Module																																																											
K	2016	Suburban	Body	Liftgate Control Module																																																											
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																											
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																											
K	2016	Suburban	Body	Keyless Entry Control Module																																																											
K	2016	Suburban	Body	Assist Step Control Module																																																											
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																											
K	2016	Suburban	Body	Parking Assist Control Module																																																											
K	2016	Suburban	Body	Frontview Camera Module																																																											
K	2016	Suburban	Body	Steering Column Lock Control Module																																																											
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																											
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																											
K	2016	Tahoe	Chassis	Power Steering Control Module																																																											
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2016	Tahoe	Chassis	Suspension Control Module																																																											
K	2016	Tahoe	Body	Body Control Module																																																											
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2016	Tahoe	Body	Passenger Presence Module																																																											
K	2016	Tahoe	Body	Instrument Cluster																																																											
K	2016	Tahoe	Body	Radio Controls																																																											
K	2016	Tahoe	Body	HVAC Controls																																																											
K	2016	Tahoe	Body	Radio																																																											
K	2016	Tahoe	Body	Amplifier																																																											
K	2016	Tahoe	Body	Media Disc Player																																																											
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																											
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																											
K	2016	Tahoe	Body	HVAC Control Module																																																											
K	2016	Tahoe	Body	Liftgate Control Module																																																											
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																											
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																											
K	2016	Tahoe	Body	Keyless Entry Control Module																																																											
K	2016	Tahoe	Body	Assist Step Control Module																																																											
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																											
K	2016	Tahoe	Body	Parking Assist Control Module																																																											
K	2016	Tahoe	Body	Frontview Camera Module																																																											
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																											
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2004	ALL	Chassis	4WAL 3 Sensor																																																										
L	2004	ALL	Body	Body Control Module																																																										
L	2004	ALL	Body	Instrument Panel Cluster																																																										
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2005	Astro	Chassis	4WAL 3 Sensor																																																										
L	2005	Astro	Body	Body Control Module																																																										
L	2005	Astro	Body	Instrument Panel Cluster																																																										
L	2005	Astro	Body	Supplemental Inflatable Restraint																																																										
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module		V																																																								
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																																										
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																																										
L	2005	Equinox	Chassis	Electric Power Steering																																																										
L	2005	Equinox	Body	Body Control Module																								V																																		
L	2005	Equinox	Body	Instrument Panel Cluster																																																										
L	2005	Equinox	Body	Radio								V																																																		
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module		V																																																								
L	2006	ALL	Chassis	Traction Control Yes																																																										
L	2006	ALL	Chassis	Traction Control No																																																										
L	2006	ALL	Chassis	Electric Power Steering																																																										
L	2006	ALL	Body	Body Control Module																								V																																		
L	2006	ALL	Body	Instrument Panel Cluster																																																										
L	2006	ALL	Body	Radio								V																																															V			
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module	V			V						V																																																
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module		V																																																								
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																																										
L	2007	ALL	Chassis	Power Steering Control Module																																																										
L	2007	ALL	Body	Body Control Module															V	V	V	V	V	V	V		V	V																																		
L	2007	ALL	Body	Digital Radio Receiver																																																										
L	2007	ALL	Body	Heated Seat Module																																	V				V																					
L	2007	ALL	Body	HVAC Control Module																													V																													
L	2007	ALL	Body	Instrument Panel Cluster																																																										
L	2007	ALL	Body	Passenger Presence System																																									V	V																
L	2007	ALL	Body	Radio																																																										
L	2007	ALL	Body	Rollover Sensor																																																										
L	2007	ALL	Body	Supplemental Inflatable Restraint																																									V									V								
L	2007	ALL	Body	Theft Deterrent Module																																																										
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module	V																																																									
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V			V																																																						
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module		V																																																							
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																																									
L	2008	Captiva Sport	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																									
L	2008	Captiva Sport	Body	HVAC Control Module Auto																												V	V																													
L	2008	Captiva Sport	Body	HVAC Control Module Manual																													V																													
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																																									
L	2008	Captiva Sport	Body	Passenger Presence System																																										V	V														
L	2008	Captiva Sport	Body	Radio																																																									
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																																									
L	2008	Captiva Sport	Body	Rollover Sensor																																																									
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																								V										V					
L	2008	Captiva Sport	Body	Theft Deterrent Module																																																									
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module	V			V																																																					
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																									
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module		V																																																							
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module				V																																																					
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																									
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module		V																																																							
L	2008	Equinox	Chassis	Electronic Brake Control Module																																																									
L	2008	Equinox	Chassis	Power Steering Control Module																																																									
L	2008	Equinox	Body	Body Control Module															V	V	V	V	V	V	V		V	V																																		
L	2008	Equinox	Body	Digital Radio Receiver																																																									
L	2008	Equinox	Body	Heated Seat Module																																	V				V																				
L	2008	Equinox	Body	HVAC Control Module																													V																													
L	2008	Equinox	Body	Instrument Panel Cluster																																																									
L	2008	Equinox	Body	Passenger Presence System																																								V	V																
L	2008	Equinox	Body	Radio																																																									
L	2008	Equinox	Body	Rollover Sensor																																																									
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																								V										V					
L	2008	Equinox	Body	Theft Deterrent Module																																																									
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module	V			V																																																					
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																									
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module	V			V																																																					
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																									
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V			V																																																					
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																									
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module		V																																																							
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																																									
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																									
L	2009	Captiva Sport	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
L	2009	Captiva Sport	Body	HVAC Control Module Auto																												V	V																													
L	2009	Captiva Sport	Body	HVAC Control Module Manual																													V																													
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																																									
L	2009	Captiva Sport	Body	Passenger Presence System																																								V	V																
L	2009	Captiva Sport	Body	Radio																																																									
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																																									
L	2009	Captiva Sport	Body	Rollover Sensor																																																									
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																								V										V					
L	2009	Captiva Sport	Body	Theft Deterrent Module																																																									
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module	V			V																																																					

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module		V																																																								
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module				V																																																						
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module		V																																																								
L	2009	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2009	Equinox	Chassis	Power Steering Control Module																																																										
L	2009	Equinox	Body	Body Control Module															V	V	V	V	V	V	V		V	V																																		
L	2009	Equinox	Body	Digital Radio Receiver																																																										
L	2009	Equinox	Body	Heated Seat Module																																	V				V																					
L	2009	Equinox	Body	HVAC Control Module																												V																														
L	2009	Equinox	Body	Instrument Panel Cluster																																																										
L	2009	Equinox	Body	Passenger Presence System																																										V	V															
L	2009	Equinox	Body	Radio																																																										
L	2009	Equinox	Body	Rollover Sensor																																																										
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																										V									V						
L	2009	Equinox	Body	Theft Deterrent Module																																																										
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module	V			V																																																							
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																										
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module	V			V																																																						
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																										
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module	V			V																																																						
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module		V																																																								
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																										
L	2010	Captiva Sport	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
L	2010	Captiva Sport	Body	HVAC Control Module																												V	V																														
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2010	Captiva Sport	Body	Passenger Presence System																																										V	V															
L	2010	Captiva Sport	Body	Radio																																																										
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2010	Captiva Sport	Body	Rollover Sensor																																																										
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																										V									V						
L	2010	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																										
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																										
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																										
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2010	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2010	Equinox	Body	Body Control Module																																																										
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2010	Equinox	Body	Passenger Presence Module																																																										
L	2010	Equinox	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2010	Equinox	Body	Radio																																																										
L	2010	Equinox	Body	Multimedia Player Interface Module																																																											
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											
L	2010	Equinox	Body	Liftgate Control Module																																																											
L	2010	Equinox	Body	Parking Assist Control Module																																																											
L	2010	Equinox	Body	Frontview Camera Module																																																											
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																																											
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																											
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																											
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																											
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																											
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																											
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																											
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																											
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																											
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																											
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																											
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																											
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																											
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
L	2011	Captiva	Chassis	Electronic Brake Control Module																																																											
L	2011	Captiva	Chassis	Parking Brake Control Module																																																											
L	2011	Captiva	Body	Body Control Module																																																											
L	2011	Captiva	Body	Auxiliary Body Control Module																																																											
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2011	Captiva	Body	Instrument Cluster																																																											
L	2011	Captiva	Body	Headlamp Control Module																																																											
L	2011	Captiva	Body	HVAC Control Module																																																											
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																											
L	2011	Captiva	Body	Parking Assist Control Module																																																											
L	2011	Captiva	Body	Theft Deterrent Module																																																											
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module	V			V																																																							
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																											
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																											
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module		V																																																									
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module	V			V																																																							
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																											
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																											
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module		V																																																									
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module	V			V					V																																																		
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																											
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																											
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module		V																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module														V																																												
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																																											
L	2011	Captiva Sport	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																											
L	2011	Captiva Sport	Body	HVAC Control Module																												V	V																															
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																																											
L	2011	Captiva Sport	Body	Passenger Presence System																																										V	V																
L	2011	Captiva Sport	Body	Radio																																																											
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																																											
L	2011	Captiva Sport	Body	Rollover Sensor																																																											
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																																																											
L	2011	Captiva Sport	Body	Theft Deterrent Module																																																											
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																																												
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																												
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																												
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2011	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2011	Equinox	Body	Body Control Module																																																												
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2011	Equinox	Body	Passenger Presence Module																																																												
L	2011	Equinox	Body	Instrument Cluster																																																												
L	2011	Equinox	Body	Radio																																																											
L	2011	Equinox	Body	Multimedia Player Interface Module																																																												
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2011	Equinox	Body	Liftgate Control Module																																																												
L	2011	Equinox	Body	Parking Assist Control Module																																																												
L	2011	Equinox	Body	Frontview Camera Module																																																												
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																																																												
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																												
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																												
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																												
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																												
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																												
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
L	2012	Captiva	Chassis	Electronic Brake Control Module																																																										
L	2012	Captiva	Chassis	Parking Brake Control Module																																																										
L	2012	Captiva	Body	Body Control Module																																																										
L	2012	Captiva	Body	Auxiliary Body Control Module																																																										
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2012	Captiva	Body	Instrument Cluster																																																										
L	2012	Captiva	Body	Headlamp Control Module																																																										
L	2012	Captiva	Body	HVAC Control Module																																																										
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																										
L	2012	Captiva	Body	Parking Assist Control Module																																																										
L	2012	Captiva	Body	Theft Deterrent Module																																																										
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module	V			V					V																																																	
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																										
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																										
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module		V																																																								
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module	V			V					V																																																	
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																										
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module		V																																																								
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module														V																																											
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																																										
L	2012	Captiva Sport	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2012	Captiva Sport	Body	HVAC Control Module																												V	V																														
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2012	Captiva Sport	Body	Passenger Presence System																																										V	V																
L	2012	Captiva Sport	Body	Radio																																																										
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2012	Captiva Sport	Body	Rollover Sensor																																																										
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2012	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																										
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2012	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2012	Equinox	Body	Body Control Module																																																										
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2012	Equinox	Body	Passenger Presence Module																																																										
L	2012	Equinox	Body	Instrument Cluster																																																										
L	2012	Equinox	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2012	Equinox	Body	Multimedia Player Interface Module																																																										
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2012	Equinox	Body	Liftgate Control Module																																																										
L	2012	Equinox	Body	Parking Assist Control Module																																																										
L	2012	Equinox	Body	Frontview Camera Module																																																										
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																																										
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																										
L	2013	Captiva	Chassis	Parking Brake Control Module																																																										
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																										
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																										
L	2013	Captiva	Body	Auxiliary Body Control Module																																																										
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2013	Captiva	Body	Instrument Cluster																																																										
L	2013	Captiva	Body	Headlamp Control Module																																																										
L	2013	Captiva	Body	HVAC Control Module																																																										
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2013	Captiva	Body	Theft Deterrent Module																																																										
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module	V			V					V																																																	
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																										
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module		V																																																								
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module	V			V					V																																																	
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																										
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module		V																																																								
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module														V																																											
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																										
L	2013	Captiva Sport	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2013	Captiva Sport	Body	Heated Seat Module																																	V				V																					
L	2013	Captiva Sport	Body	HVAC Control Module																												V	V																													
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2013	Captiva Sport	Body	Park Assist Module																																							V	V	V																
L	2013	Captiva Sport	Body	Passenger Presence System																																										V	V														
L	2013	Captiva Sport	Body	Radio																																																								
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																								
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																																								
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																								
L	2013	Captiva Sport	Body	Theft Deterrent Module																																																								
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																								
L	2013	Equinox	Chassis	Electronic Brake Control Module																																																								
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2013	Equinox	Chassis	Power Steering Control Module																																																								
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																								
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																								
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2013	Equinox	Body	Passenger Presence Module																																																								
L	2013	Equinox	Body	Instrument Cluster																																																								
L	2013	Equinox	Body	Radio																																																								
L	2013	Equinox	Body	Rear Audio Control Module																																																								
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																								
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																								
L	2013	Equinox	Body	Liftgate Control Module																																																								
L	2013	Equinox	Body	Front Seat Heating Control Module																																																								
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																								
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																								
L	2013	Equinox	Body	Parking Assist Control Module																																																								
L	2013	Equinox	Body	Frontview Camera Module																																																								
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																								
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																								
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																								
L	2014	Captiva (3GN)	Body	Body Control Module																																																								
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																								
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																								
L	2014	Captiva (3GN)	Body	Radio																																																								
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																								
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																								
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																								
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																											
L	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																											
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																											
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																											
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																											
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2014	Captiva (Other)	Body	Instrument Cluster																																																											
L	2014	Captiva (Other)	Body	Headlamp Control Module																																																											
L	2014	Captiva (Other)	Body	HVAC Control Module																																																											
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
L	2014	Captiva (Other)	Body	Theft Deterrent Module																																																											
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																											
L	2014	Equinox	Chassis	Electronic Brake Control Module																																																											
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2014	Equinox	Chassis	Power Steering Control Module																																																											
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																											
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2014	Equinox	Body	Passenger Presence Module																																																											
L	2014	Equinox	Body	Instrument Cluster																																																											
L	2014	Equinox	Body	Radio																																																											
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2014	Equinox	Body	Liftgate Control Module																																																									
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Parking Assist Control Module																																																										
L	2014	Equinox	Body	Frontview Camera Module																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (3GN)	Body	Body Control Module																																																										
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																																										
L	2015	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2015	Captiva (3GN)	Body	Radio																																																										
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
L	2015	Captiva (3GN)	Body	HVAC Control Module																																																										
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (Other)	Body	Instrument Cluster																																																										
L	2015	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2015	Captiva (Other)	Body	HVAC Control Module																																																										
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2015	Captiva (Other)	Body	Theft Deterrent Module																																																											
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																											
L	2015	Equinox	Chassis	Electronic Brake Control Module																																																											
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2015	Equinox	Chassis	Power Steering Control Module																																																											
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																																											
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2015	Equinox	Body	Passenger Presence Module																																																											
L	2015	Equinox	Body	Instrument Cluster																																																											
L	2015	Equinox	Body	Radio																																																											
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																																											
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											
L	2015	Equinox	Body	Liftgate Control Module																																																											
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																											
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																											
L	2015	Equinox	Body	Parking Assist Control Module																																																											
L	2015	Equinox	Body	Frontview Camera Module																																																											
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																											
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																											
L	2016	Captiva (3GN)	Body	Body Control Module																																																											
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2016	Captiva (3GN)	Body	Instrument Cluster																																																											
L	2016	Captiva (3GN)	Body	Radio																																																											
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																											
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																											
L	2016	Captiva (3GN)	Body	HVAC Control Module																																																											
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																											
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																											
L	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Captiva (Other)	Body	Instrument Cluster																																																										
L	2016	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2016	Captiva (Other)	Body	Radio																																																										
L	2016	Captiva (Other)	Body	HVAC Control Module																																																										
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2016	Captiva (Other)	Body	Theft Deterrent Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2016	Equinox	Chassis	Power Steering Control Module																																																										
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Equinox	Body	Passenger Presence Module																																																										
L	2016	Equinox	Body	Instrument Cluster																																																										
L	2016	Equinox	Body	Radio																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2016	Equinox	Body	Liftgate Control Module																																																										
L	2016	Equinox	Body	Seat Memory Control Module																																																										
L	2016	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Parking Assist Control Module																																																										
L	2016	Equinox	Body	Frontview Camera Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
M	2004	ALL	Chassis	4WAL 3 Sensor																																																										
M	2004	ALL	Body	Body Control Module																																																										
M	2004	ALL	Body	Instrument Panel Cluster																																																										
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
M	2005	ALL	Chassis	4WAL 3 Sensor																																																										
M	2005	ALL	Body	Body Control Module																																																										
M	2005	ALL	Body	Instrument Panel Cluster																																																										
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
P	2007	ALL	Body	Theft Deterrent Module																																																										
R	2009	ALL	Powertrain	Engine Control Module				V						V																																																
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2009	ALL	Powertrain	Transmission Control Module		V																																																								
R	2009	ALL	Chassis	Electronic Brake Control Module													V																																												
R	2009	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
R	2009	ALL	Body	Digital Radio Receiver																																																									
R	2009	ALL	Body	Driver Door Switch																																																									
R	2009	ALL	Body	Heated Seat Module																														V	V																										
R	2009	ALL	Body	HVAC Control Module Auto																												V	V																											
R	2009	ALL	Body	HVAC Control Module Manual																													V																											
R	2009	ALL	Body	Instrument Panel Cluster																																																								
R	2009	ALL	Body	Lift Gate Module																																																								
R	2009	ALL	Body	Park Assist Module																																							V	V	V															
R	2009	ALL	Body	Passenger Door Switch																																																								
R	2009	ALL	Body	Passenger Presence System																																									V														
R	2009	ALL	Body	Radio																																																								
R	2009	ALL	Body	Rear HVAC/RSA																																																								
R	2009	ALL	Body	Rollover Sensor																																																								
R	2009	ALL	Body	Supplemental Inflatable Restraint																																									V									V				
R	2009	ALL	Body	Theft Deterrent Module																																																								
R	2010	ALL	Powertrain	Engine Control Module				V																																																					
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2010	ALL	Powertrain	Transmission Control Module		V																																																								
R	2010	ALL	Chassis	Electronic Brake Control Module													V																																												
R	2010	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
R	2010	ALL	Body	Digital Radio Receiver																																																									
R	2010	ALL	Body	Driver Door Switch																																																									
R	2010	ALL	Body	Heated Seat Module																														V	V																										
R	2010	ALL	Body	HVAC Control Module Auto																												V	V																											
R	2010	ALL	Body	HVAC Control Module Manual																													V																											
R	2010	ALL	Body	Instrument Panel Cluster																																																								
R	2010	ALL	Body	Lift Gate Module																																																								
R	2010	ALL	Body	Park Assist Module																																							V	V	V															
R	2010	ALL	Body	Passenger Door Switch																																																								
R	2010	ALL	Body	Passenger Presence System																																									V														
R	2010	ALL	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2010	ALL	Body	Rear HVAC/RSA																																																									
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2010	ALL	Body	Theft Deterrent Module																																																										
R	2011	ALL	Powertrain	Engine Control Module				V																																																						
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2011	ALL	Powertrain	Transmission Control Module		V																																																								
R	2011	ALL	Chassis	Electronic Brake Control Module													V																																												
R	2011	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
R	2011	ALL	Body	Digital Radio Receiver																																																										
R	2011	ALL	Body	Driver Door Switch																																																										
R	2011	ALL	Body	Heated Seat Module																														V	V																												
R	2011	ALL	Body	HVAC Control Module Auto																												V	V																													
R	2011	ALL	Body	HVAC Control Module Manual																													V																														
R	2011	ALL	Body	Instrument Panel Cluster																																																										
R	2011	ALL	Body	Lift Gate Module																																																										
R	2011	ALL	Body	Park Assist Module																																							V	V	V																	
R	2011	ALL	Body	Passenger Door Switch																																																										
R	2011	ALL	Body	Passenger Presence System																																										V																
R	2011	ALL	Body	Radio																																																										
R	2011	ALL	Body	Rear HVAC/RSA																																																										
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2011	ALL	Body	Theft Deterrent Module																																																										
R	2012	ALL	Powertrain	Engine Control Module	V			V					V																																																	
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2012	ALL	Powertrain	Transmission Control Module		V																																																								
R	2012	ALL	Chassis	Electronic Brake Control Module													V																																												
R	2012	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
R	2012	ALL	Body	Digital Radio Receiver																																																										
R	2012	ALL	Body	Driver Door Switch																																																										
R	2012	ALL	Body	Heated Seat Module																														V	V																												
R	2012	ALL	Body	HVAC Control Module Auto																												V	V																													
R	2012	ALL	Body	HVAC Control Module Manual																													V																														
R	2012	ALL	Body	Instrument Panel Cluster																																																										
R	2012	ALL	Body	Lift Gate Module																																																										
R	2012	ALL	Body	Park Assist Module																																							V	V	V																	
R	2012	ALL	Body	Passenger Door Switch																																																										
R	2012	ALL	Body	Passenger Presence System																																										V																
R	2012	ALL	Body	Radio																																																										
R	2012	ALL	Body	Rear HVAC/RSA																																																										
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2012	ALL	Body	Theft Deterrent Module																																																										
R	2013	ALL	Powertrain	Engine Control Module	V			V					V																																																	
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2013	ALL	Powertrain	Transmission Control Module		V																																																								
R	2013	ALL	Chassis	Electronic Brake Control Module													V																																												
R	2013	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
R	2013	ALL	Body	Digital Radio Receiver																																																										
R	2013	ALL	Body	Driver Door Switch																																																										
R	2013	ALL	Body	Heated Seat Module																														V	V																												
R	2013	ALL	Body	HVAC Control Module Auto																												V	V																													
R	2013	ALL	Body	HVAC Control Module Manual																													V																														

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2013	ALL	Body	Instrument Panel Cluster																																																											
R	2013	ALL	Body	Left Side Object Detection Module																																																												
R	2013	ALL	Body	Lift Gate Module																																																												
R	2013	ALL	Body	Park Assist Module																																							V	V	V																		
R	2013	ALL	Body	Passenger Door Switch																																																											
R	2013	ALL	Body	Passenger Presence System																																										V																	
R	2013	ALL	Body	Radio																																																											
R	2013	ALL	Body	Rear HVAC/RSA																																																												
R	2013	ALL	Body	Right Side Object Detection Module																																																												
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2013	ALL	Body	Theft Deterrent Module																																																												
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2014	Traverse	Powertrain	Chassis Control Module																																																												
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
R	2014	Traverse	Chassis	Electronic Brake Control Module																																																												
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																												
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Traverse	Body	Passenger Presence Module																																																												
R	2014	Traverse	Body	Instrument Cluster																																																												
R	2014	Traverse	Body	Radio																																																												
R	2014	Traverse	Body	Rear Audio Control Module																																																												
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																												
R	2014	Traverse	Body	Personal Audio Link Control Module																																																												
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																												
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																												
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																												
R	2014	Traverse	Body	Liftgate Control Module																																																												
R	2014	Traverse	Body	Seat Memory Control Module																																																												
R	2014	Traverse	Body	Front Seat Heating Control Module																																																												
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																												
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																												
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																												
R	2014	Traverse	Body	Parking Assist Control Module																																																												
R	2014	Traverse	Body	Frontview Camera Module																																																												
R	2014	Traverse	Body	Theft Deterrent Module																																																												
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
R	2015	Traverse	Chassis	Electronic Brake Control Module																																																												
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																												
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Traverse	Body	Passenger Presence Module																																																												
R	2015	Traverse	Body	Instrument Cluster																																																												
R	2015	Traverse	Body	Radio																																																												
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																									
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																									
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																									
R	2015	Traverse	Body	Liftgate Control Module																																																									
R	2015	Traverse	Body	Seat Memory Control Module																																																									
R	2015	Traverse	Body	Front Seat Heating Control Module																																																									
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																									
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																									
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																									
R	2015	Traverse	Body	Parking Assist Control Module																																																									
R	2015	Traverse	Body	Frontview Camera Module																																																									
R	2015	Traverse	Body	Theft Deterrent Module																																																									
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																									
R	2016	Traverse	Chassis	Electronic Brake Control Module																																																									
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																									
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																									
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
R	2016	Traverse	Body	Passenger Presence Module																																																									
R	2016	Traverse	Body	Instrument Cluster																																																									
R	2016	Traverse	Body	Radio																																																									
R	2016	Traverse	Body	Rear Audio Control Module																																																									
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																									
R	2016	Traverse	Body	Personal Audio Link Control Module																																																									
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																									
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																									
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																									
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																									
R	2016	Traverse	Body	Liftgate Control Module																																																									
R	2016	Traverse	Body	Seat Memory Control Module																																																									
R	2016	Traverse	Body	Front Seat Heating Control Module																																																									
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																									
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																									
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																									
R	2016	Traverse	Body	Parking Assist Control Module																																																									
R	2016	Traverse	Body	Frontview Camera Module																																																									
R	2016	Traverse	Body	Theft Deterrent Module																																																									
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
S	2004	S10	Chassis	4WAL 3 Sensor																																																									
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																									
S	2004	S10	Body	Body Control Module																																																									
S	2004	S10	Body	Instrument Panel Cluster																																																									
S	2004	S10	Body	Base Radio																																																									
S	2004	S10	Body	Uplevel Radio																																																									
S	2004	S10	Body	Supplemental Inflatable Restraint																																																									
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2004	Colorado	Chassis	ABS Without Traction Control																																																												
S	2004	Colorado	Chassis	ABS With Traction Control																																																												
S	2004	Colorado	Body	Body Control Module																																																												
S	2004	Colorado	Body	Instrument Panel Cluster																																																												
S	2004	Colorado	Body	OnStar																																																												
S	2004	Colorado	Body	Base Radio																																																												
S	2004	Colorado	Body	Uplevel Radio																																																												
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																												
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																												
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																												
S	2004	TrailBlazer	Body	Body Control Module																																																												
S	2004	TrailBlazer	Body	Driver Door Module																																																												
S	2004	TrailBlazer	Body	Driver Seat Module																																																												
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																												
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																												
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2004	TrailBlazer	Body	Lift Gate Module																																																												
S	2004	TrailBlazer	Body	OnStar																																																												
S	2004	TrailBlazer	Body	Passenger Door Module																																																												
S	2004	TrailBlazer	Body	Uplevel Radio																																																												
S	2004	TrailBlazer	Body	Navigation Radio																																																												
S	2004	TrailBlazer	Body	Rear Seat Audio																																																												
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																												
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																												
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																												
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																												
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																												
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																												
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																												
S	2004	TrailBlazer EXT	Body	Body Control Module																																																												
S	2004	TrailBlazer EXT	Body	Driver Door Module																																																												
S	2004	TrailBlazer EXT	Body	Driver Seat Module																																																												
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																												
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																												
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																												
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																												
S	2004	TrailBlazer EXT	Body	OnStar																																																												
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																																												
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																												
S	2004	TrailBlazer EXT	Body	Navigation Radio																																																												
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																											
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																											
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																											
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																											
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																											
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Blazer	Body	Body Control Module																																																											
S	2004	Blazer	Body	Heating and Air Conditioning																																																											
S	2004	Blazer	Body	Instrument Panel Cluster																																																											
S	2004	Blazer	Body	Memory Seat Module																																																											
S	2004	Blazer	Body	Base Radio																																																											
S	2004	Blazer	Body	Uplevel Radio																																																											
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																																											
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																											
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																											
S	2004	SSR	Chassis	4WAL 3 Sensor																																																											
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																											
S	2004	SSR	Body	Amplifier (Bose)																																																											
S	2004	SSR	Body	Body Control Module																																																											
S	2004	SSR	Body	Driver Seat Module																																																											
S	2004	SSR	Body	Instrument Panel Cluster																																																											
S	2004	SSR	Body	Uplevel Radio																																																											
S	2004	SSR	Body	Remote Function Actuation																																																											
S	2004	SSR	Body	Roof and Door Module																																																											
S	2004	SSR	Body	Supplemental Inflatable Restraint																																																											
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2005	Colorado	Chassis	ABS Without Traction Control																																																											
S	2005	Colorado	Chassis	ABS With Traction Control																																																											
S	2005	Colorado	Body	Body Control Module																																																											
S	2005	Colorado	Body	Instrument Panel Cluster																																																											
S	2005	Colorado	Body	Base Radio																																																											
S	2005	Colorado	Body	Uplevel Radio																																																											
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																																											
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																																											
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																											
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																											
S	2005	TrailBlazer	Body	Body Control Module																																																											
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																											
S	2005	TrailBlazer	Body	Driver Door Module																																																											
S	2005	TrailBlazer	Body	Driver Seat Module																																																											
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																											
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																											
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2005	TrailBlazer	Body	Lift Gate Module																																																										
S	2005	TrailBlazer	Body	Passenger Door Module																																																											
S	2005	TrailBlazer	Body	Passenger Presence System																																																											
S	2005	TrailBlazer	Body	Uplevel Radio																																																											
S	2005	TrailBlazer	Body	Navigation Radio																																																											
S	2005	TrailBlazer	Body	Rear Seat Audio																																																											
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																											
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																											
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																											
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																											
S	2005	TrailBlazer EXT	Body	Body Control Module																																																											
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																											
S	2005	TrailBlazer EXT	Body	Driver Door Module																																																											
S	2005	TrailBlazer EXT	Body	Driver Seat Module																																																											
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																											
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																											
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																											
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																											
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																																											
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																											
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																											
S	2005	TrailBlazer EXT	Body	Navigation Radio																																																											
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																											
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																											
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																											
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																											
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																											
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																											
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																											
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																											
S	2005	Blazer	Body	Body Control Module																																																											
S	2005	Blazer	Body	Heating and Air Conditioning																																																											
S	2005	Blazer	Body	Instrument Panel Cluster																																																											
S	2005	Blazer	Body	Memory Seat Module																																																											
S	2005	Blazer	Body	Base Radio																																																											
S	2005	Blazer	Body	Uplevel Radio																																																											
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																																											
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																							
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2005	SSR	Chassis	4WAL 3 Sensor																																																											
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																											
S	2005	SSR	Body	Amplifier (Bose)																																																											
S	2005	SSR	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2005	SSR	Body	Driver Seat Module																																																										
S	2005	SSR	Body	Instrument Panel Cluster																																																											
S	2005	SSR	Body	Uplevel Radio																																																											
S	2005	SSR	Body	Remote Function Actuation																																																											
S	2005	SSR	Body	Roof and Door Module																																																											
S	2005	SSR	Body	Supplemental Inflatable Restraint																																																											
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2006	Colorado	Chassis	ABS Without Traction Control																																																											
S	2006	Colorado	Chassis	ABS With Traction Control																																																											
S	2006	Colorado	Body	Body Control Module																																																											
S	2006	Colorado	Body	Instrument Panel Cluster																																																											
S	2006	Colorado	Body	Passenger Presence System																																																											
S	2006	Colorado	Body	Base Radio																																																											
S	2006	Colorado	Body	Uplevel Radio																																																											
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																																											
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																																											
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																							
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES														V																																												
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																											
S	2006	TrailBlazer	Body	Body Control Module																																																											
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																											
S	2006	TrailBlazer	Body	Driver Door Module																																																											
S	2006	TrailBlazer	Body	Driver Seat Module																																																											
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																											
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																											
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																																											
S	2006	TrailBlazer	Body	Lift Gate Module																																																											
S	2006	TrailBlazer	Body	Passenger Door Module																																																											
S	2006	TrailBlazer	Body	Passenger Presence System																																																											
S	2006	TrailBlazer	Body	Uplevel Radio																																																											
S	2006	TrailBlazer	Body	Navigation Radio																																																											
S	2006	TrailBlazer	Body	Rear Seat Audio																																																											
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																											
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																											
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES														V																																												
S	2006	TrailBlazer EXT	Body	Body Control Module																																																											
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																											
S	2006	TrailBlazer EXT	Body	Driver Door Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2006	TrailBlazer EXT	Body	Driver Seat Module																																																										
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																										
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																																										
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																										
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																										
S	2006	TrailBlazer EXT	Body	Navigation Radio																																																										
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																										
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																										
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																						
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2006	SSR	Chassis	4WAL 3 Sensor																																																										
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																										
S	2006	SSR	Body	Amplifier (Bose)																																																										
S	2006	SSR	Body	Body Control Module																																																										
S	2006	SSR	Body	Driver Seat Module																																																										
S	2006	SSR	Body	Instrument Panel Cluster																																																										
S	2006	SSR	Body	Uplevel Radio																																																										
S	2006	SSR	Body	Remote Function Actuation																																																										
S	2006	SSR	Body	Roof and Door Module																																																										
S	2006	SSR	Body	Supplemental Inflatable Restraint																																																										
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module									V	V																																																
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module									V	V																																																
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																										
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																										
S	2007	Colorado	Body	Body Control Module																																																										
S	2007	Colorado	Body	Digital Radio Receiver																																																										
S	2007	Colorado	Body	Generator Battery Control Module																																																										
S	2007	Colorado	Body	Instrument Panel Cluster																																																										
S	2007	Colorado	Body	Passenger Presence System																																																										
S	2007	Colorado	Body	Base Radio																																																										
S	2007	Colorado	Body	Uplevel Radio																																																										
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																																										
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module									V	V																																																
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module									V	V																																																
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																										
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																						
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																						
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2007	Trailblazer	Chassis	Electronic Brake Control Module														V																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2007	Trailblazer	Body	Body Control Module																																																										
S	2007	Trailblazer	Body	Digital Radio Receiver																																																											
S	2007	Trailblazer	Body	Disc Player and Video Display																																																											
S	2007	Trailblazer	Body	Driver Door Module																																																											
S	2007	Trailblazer	Body	Driver Seat Module																																																											
S	2007	Trailblazer	Body	Generator Battery Control Module																																																											
S	2007	Trailblazer	Body	HVAC Control Module Auto																																																											
S	2007	Trailblazer	Body	HVAC Control Module Manual																																																											
S	2007	Trailblazer	Body	Instrument Panel Cluster																																																											
S	2007	Trailblazer	Body	Lift Gate Module																																																											
S	2007	Trailblazer	Body	Passenger Door Module																																																											
S	2007	Trailblazer	Body	Passenger Presence System																																																											
S	2007	Trailblazer	Body	Uplevel Radio																																																											
S	2007	Trailblazer	Body	Navigation Radio																																																											
S	2007	Trailblazer	Body	Rear Seat Audio																																																											
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																											
S	2007	Trailblazer	Body	Theft Deterrent Module																																																											
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																											
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																	
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module				V					V	V																																																		
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2008	Colorado	Body	Body Control Module																																																											
S	2008	Colorado	Body	Digital Radio Receiver																																																											
S	2008	Colorado	Body	Generator Battery Control Module																																																											
S	2008	Colorado	Body	Instrument Panel Cluster																																																											
S	2008	Colorado	Body	Passenger Presence System																																																											
S	2008	Colorado	Body	Base Radio																																																											
S	2008	Colorado	Body	Uplevel Radio																																																											
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																																											
S	2008	Colorado	Body	Theft Deterrent Module																																																											
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																																											
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module				V					V	V																																																	
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																							
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module														V																																												
S	2008	TrailBlazer	Body	Body Control Module																																																											
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																											
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																											
S	2008	TrailBlazer	Body	Driver Door Module																																																											
S	2008	TrailBlazer	Body	Driver Seat Module																																																											
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																											
S	2008	TrailBlazer	Body	HVAC Control Module Auto																																																											
S	2008	TrailBlazer	Body	HVAC Control Module Manual																																																											
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																																											
S	2008	TrailBlazer	Body	Lift Gate Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2008	TrailBlazer	Body	Passenger Door Module																																																										
S	2008	TrailBlazer	Body	Passenger Presence System																																																											
S	2008	TrailBlazer	Body	Uplevel Radio																																																											
S	2008	TrailBlazer	Body	Navigation Radio																																																											
S	2008	TrailBlazer	Body	Rear Seat Audio																																																											
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
S	2008	TrailBlazer	Body	Theft Deterrent Module																																																											
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																											
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																	
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																		
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module	V			V																																																								
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																												
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																												
S	2009	Colorado	Chassis	Electronic Brake Control Module																																																												
S	2009	Colorado	Body	Body Control Module																																																												
S	2009	Colorado	Body	Digital Radio Receiver																																																												
S	2009	Colorado	Body	Generator Battery Control Module																																																												
S	2009	Colorado	Body	Instrument Panel Cluster																																																												
S	2009	Colorado	Body	Passenger Presence System																																																												
S	2009	Colorado	Body	Base Radio																																																											
S	2009	Colorado	Body	Uplevel Radio																																																											
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																																											
S	2009	Colorado	Body	Theft Deterrent Module																																																											
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module				V						V																																																	
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																											
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																							
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																											
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module														V																																												
S	2009	TrailBlazer	Body	Body Control Module																																																											
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																											
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																											
S	2009	TrailBlazer	Body	Driver Door Module																																																											
S	2009	TrailBlazer	Body	Driver Seat Module																																																											
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																											
S	2009	TrailBlazer	Body	HVAC Control Module Auto																																																											
S	2009	TrailBlazer	Body	HVAC Control Module Manual																																																											
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																																											
S	2009	TrailBlazer	Body	Lift Gate Module																																																											
S	2009	TrailBlazer	Body	Passenger Door Module																																																											
S	2009	TrailBlazer	Body	Passenger Presence System																																																											
S	2009	TrailBlazer	Body	Uplevel Radio																																																											
S	2009	TrailBlazer	Body	Navigation Radio																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2009	TrailBlazer	Body	Rear Seat Audio																																																										
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2009	TrailBlazer	Body	Theft Deterrent Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V			V																																																						
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2010	ALL	Chassis	Electronic Brake Control Module																																																										
S	2010	ALL	Body	Body Control Module																																																									
S	2010	ALL	Body	Digital Radio Receiver																																																									
S	2010	ALL	Body	Generator Battery Control Module																																																									
S	2010	ALL	Body	Instrument Panel Cluster																																																									
S	2010	ALL	Body	Passenger Presence System																																																									
S	2010	ALL	Body	Personal Audio Link Module																																																									
S	2010	ALL	Body	Base Radio																																																									
S	2010	ALL	Body	Uplevel Radio																																																									
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
S	2010	ALL	Body	Theft Deterrent Module																																																									
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																									
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V			V																																																						
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2011	ALL	Chassis	Electronic Brake Control Module																																																										
S	2011	ALL	Body	Body Control Module																																																									
S	2011	ALL	Body	Digital Radio Receiver																																																									
S	2011	ALL	Body	Generator Battery Control Module																																																									
S	2011	ALL	Body	Instrument Panel Cluster																																																									
S	2011	ALL	Body	Passenger Presence System																																																									
S	2011	ALL	Body	Personal Audio Link Module																																																									
S	2011	ALL	Body	Base Radio																																																									
S	2011	ALL	Body	Uplevel Radio																																																									
S	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
S	2011	ALL	Body	Theft Deterrent Module																																																									
S	2011	ALL	Body	Vehicle Comm. Interface Module																																																									
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V			V																																																							
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																											
S	2012	Colorado (First Gen)	Body	Body Control Module																																																											
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																											
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																											
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																											
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																											
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																											
S	2012	Colorado (First Gen)	Body	Base Radio																																																											
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																											
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																											
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																											
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																											
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																											
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																											
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																											
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																											
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2012	Colorado (Second Gen)	Body	Body Control Module																																																											
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																											
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																											
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																											
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																											
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																											
S	2012	S10	Powertrain	Transfer Case Control Module																																																											
S	2012	S10	Chassis	Electronic Brake Control Module																																																											
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2012	S10	Body	Body Control Module																																																										
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2012	S10	Body	Instrument Cluster																																																											
S	2012	S10	Body	Trailer Interface Control Module																																																											
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																											
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																											
S	2013	Colorado	Powertrain	Transfer Case Control Module																																																											
S	2013	Colorado	Chassis	Electronic Brake Control Module																																																											
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2013	Colorado	Body	Body Control Module																																																											
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2013	Colorado	Body	Instrument Cluster																																																											
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																											
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																											
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																											
S	2013	S10	Powertrain	Transfer Case Control Module																																																											
S	2013	S10	Chassis	Electronic Brake Control Module																																																											
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2013	S10	Body	Body Control Module																																																											
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2013	S10	Body	Instrument Cluster																																																											
S	2013	S10	Body	Trailer Interface Control Module																																																											
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																											
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																											
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																											
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																											
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2013	Trailblazer	Body	Body Control Module																																																											
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2013	Trailblazer	Body	Instrument Cluster																																																											
S	2013	Trailblazer	Body	Trailer Interface Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2013	Trailblazer	Body	Parking Assist Control Module																																																										
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																											
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																											
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																											
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																											
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2014	Colorado	Body	Body Control Module																																																											
S	2014	Colorado	Body	Body Control Module																																																											
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2014	Colorado	Body	Instrument Cluster																																																											
S	2014	Colorado	Body	Radio																																																											
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																											
S	2014	Colorado	Body	Parking Assist Control Module																																																											
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																											
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																											
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																											
S	2014	S10	Powertrain	Transfer Case Control Module																																																											
S	2014	S10	Chassis	Electronic Brake Control Module																																																											
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2014	S10	Body	Body Control Module																																																											
S	2014	S10	Body	Body Control Module																																																											
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2014	S10	Body	Instrument Cluster																																																											
S	2014	S10	Body	Trailer Interface Control Module																																																											
S	2014	S10	Body	Radio																																																											
S	2014	S10	Body	Parking Assist Control Module																																																											
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																											
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																											
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																									
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2014	Trailblazer	Body	Body Control Module																																																									
S	2014	Trailblazer	Body	Body Control Module																																																									
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	Trailblazer	Body	Instrument Cluster																																																									
S	2014	Trailblazer	Body	Trailer Interface Control Module																																																									
S	2014	Trailblazer	Body	Parking Assist Control Module																																																									
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
S	2015	Colorado	Powertrain	Chassis Control Module																																																									
S	2015	Colorado	Powertrain	Transfer Case Control Module																																																									
S	2015	Colorado	Chassis	Electronic Brake Control Module																																																									
S	2015	Colorado	Chassis	Power Steering Control Module																																																									
S	2015	Colorado	Body	Body Control Module																																																									
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2015	Colorado	Body	Passenger Presence Module																																																									
S	2015	Colorado	Body	Radio																																																									
S	2015	Colorado	Body	Amplifier																																																									
S	2015	Colorado	Body	Human Machine Interface Control Module																																																									
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																																									
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																									
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																									
S	2015	Colorado	Body	Frontview Camera Module																																																									
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																									
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																									
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2015	Colorado (MMM)	Body	Body Control Module																																																									
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2015	Colorado (MMM)	Body	Instrument Cluster																																																											
S	2015	Colorado (MMM)	Body	Radio																																																												
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																												
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																												
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2015	S10	Powertrain	Transfer Case Control Module																																																												
S	2015	S10	Chassis	Electronic Brake Control Module																																																												
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2015	S10	Body	Body Control Module																																																												
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2015	S10	Body	Instrument Cluster																																																												
S	2015	S10	Body	Trailer Interface Control Module																																																												
S	2015	S10	Body	Radio																																																												
S	2015	S10	Body	Telematics Communication Interface Control Module																																																												
S	2015	S10	Body	Parking Assist Control Module																																																												
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																												
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																												
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2015	Trailblazer	Body	Body Control Module																																																												
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2015	Trailblazer	Body	Instrument Cluster																																																												
S	2015	Trailblazer	Body	Trailer Interface Control Module																																																												
S	2015	Trailblazer	Body	Radio																																																												
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																												
S	2015	Trailblazer	Body	Parking Assist Control Module																																																												
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																												
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																										
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																										
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																										
S	2016	Colorado (1GC)	Body	Body Control Module																																																										
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																																										
S	2016	Colorado (1GC)	Body	Radio Controls																																																										
S	2016	Colorado (1GC)	Body	HVAC Controls																																																										
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																										
S	2016	Colorado (1GC)	Body	Radio																																																										
S	2016	Colorado (1GC)	Body	Amplifier																																																										
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																										
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																										
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																										
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																										
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																																										
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																										
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																										
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	Colorado (MMM)	Body	Body Control Module																																																										
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Colorado (MMM)	Body	Instrument Cluster																																																										
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																										
S	2016	Colorado (MMM)	Body	Radio																																																										
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																										
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																										
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																										
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																										
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	S10	Powertrain	Transfer Case Control Module																																																										
S	2016	S10	Chassis	Electronic Brake Control Module																																																										
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	S10	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2016	S10	Body	Instrument Cluster																																																									
S	2016	S10	Body	Trailer Interface Control Module																																																									
S	2016	S10	Body	Radio																																																									
S	2016	S10	Body	Telematics Communication Interface Control Module																																																									
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																									
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																									
S	2016	S10	Body	Parking Assist Control Module																																																									
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																									
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																									
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																									
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2016	Trailblazer	Body	Body Control Module																																																									
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2016	Trailblazer	Body	Instrument Cluster																																																									
S	2016	Trailblazer	Body	Trailer Interface Control Module																																																									
S	2016	Trailblazer	Body	Radio																																																									
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																									
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																									
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																									
S	2016	Trailblazer	Body	Parking Assist Control Module																																																									
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2004	S10	Chassis	4WAL 3 Sensor																																																									
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																									
T	2004	S10	Body	Body Control Module																																																									
T	2004	S10	Body	Instrument Panel Cluster																																																									
T	2004	S10	Body	Base Radio																																																									
T	2004	S10	Body	Uplevel Radio																																																									
T	2004	S10	Body	Supplemental Inflatable Restraint																																																									
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																									
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																									
T	2004	Colorado	Chassis	ABS Without Traction Control																																																									
T	2004	Colorado	Chassis	ABS With Traction Control																																																									
T	2004	Colorado	Body	Body Control Module																																																									
T	2004	Colorado	Body	Instrument Panel Cluster																																																									
T	2004	Colorado	Body	OnStar																																																									
T	2004	Colorado	Body	Base Radio																																																									
T	2004	Colorado	Body	Uplevel Radio																																																									
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																																									
T	2004	Colorado	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active											V																																														
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable											V																																														
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer	Body	Body Control Module																																																										
T	2004	TrailBlazer	Body	Driver Door Module																																																										
T	2004	TrailBlazer	Body	Driver Seat Module																																																										
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2004	TrailBlazer	Body	Lift Gate Module																																																										
T	2004	TrailBlazer	Body	OnStar																																																										
T	2004	TrailBlazer	Body	Passenger Door Module																																																										
T	2004	TrailBlazer	Body	Uplevel Radio																																																										
T	2004	TrailBlazer	Body	Navigation Radio																																																										
T	2004	TrailBlazer	Body	Rear Seat Audio																																																										
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display											V																																															
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display											V																																															
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer EXT	Body	Body Control Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Seat Module																																																										
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2004	TrailBlazer EXT	Body	OnStar																																																										
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2004	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																											
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Blazer	Body	Body Control Module																																																										
T	2004	Blazer	Body	Heating and Air Conditioning																																																											
T	2004	Blazer	Body	Instrument Panel Cluster																																																											
T	2004	Blazer	Body	Memory Seat Module																																																											
T	2004	Blazer	Body	Base Radio																																																											
T	2004	Blazer	Body	Uplevel Radio																																																											
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																																											
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
T	2005	Colorado	Chassis	ABS Without Traction Control																																																											
T	2005	Colorado	Chassis	ABS With Traction Control																																																											
T	2005	Colorado	Body	Body Control Module																																																											
T	2005	Colorado	Body	Instrument Panel Cluster																																																											
T	2005	Colorado	Body	Base Radio																																																											
T	2005	Colorado	Body	Uplevel Radio																																																											
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																																											
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																																											
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active											V																																															
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																											
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																											
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																											
T	2005	TrailBlazer	Body	Body Control Module																																																											
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																											
T	2005	TrailBlazer	Body	Driver Door Module																																																											
T	2005	TrailBlazer	Body	Driver Seat Module																																																											
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																											
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																											
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																																											
T	2005	TrailBlazer	Body	Lift Gate Module																																																											
T	2005	TrailBlazer	Body	Passenger Door Module																																																											
T	2005	TrailBlazer	Body	Passenger Presence System																																																											
T	2005	TrailBlazer	Body	Uplevel Radio																																																											
T	2005	TrailBlazer	Body	Navigation Radio																																																											
T	2005	TrailBlazer	Body	Rear Seat Audio																																																											
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																											
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																											
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display											V																																															
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																						
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display											V																																															

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																											
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																											
T	2005	TrailBlazer EXT	Body	Body Control Module																																																											
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																											
T	2005	TrailBlazer EXT	Body	Driver Door Module																																																											
T	2005	TrailBlazer EXT	Body	Driver Seat Module																																																											
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																											
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																											
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																											
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																											
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																																											
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																											
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																											
T	2005	TrailBlazer EXT	Body	Navigation Radio																																																											
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																											
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																											
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																											
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																											
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																											
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																											
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																											
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																											
T	2005	Blazer	Body	Body Control Module																																																											
T	2005	Blazer	Body	Heating and Air Conditioning																																																											
T	2005	Blazer	Body	Instrument Panel Cluster																																																											
T	2005	Blazer	Body	Memory Seat Module																																																											
T	2005	Blazer	Body	Base Radio																																																											
T	2005	Blazer	Body	Uplevel Radio																																																											
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																																											
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
T	2006	Colorado	Chassis	ABS Without Traction Control																																																											
T	2006	Colorado	Chassis	ABS With Traction Control																																																											
T	2006	Colorado	Body	Body Control Module																																																											
T	2006	Colorado	Body	Instrument Panel Cluster																																																											
T	2006	Colorado	Body	Passenger Presence System																																																											
T	2006	Colorado	Body	Base Radio																																																											
T	2006	Colorado	Body	Uplevel Radio																																																											
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																																											
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																																											
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display											V																																															
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																						
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display											V																																																
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																							
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES														V																																												
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																											
T	2006	TrailBlazer	Body	Body Control Module																																																											
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																											
T	2006	TrailBlazer	Body	Driver Door Module																																																											
T	2006	TrailBlazer	Body	Driver Seat Module																																																											
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																											
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																											
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																																											
T	2006	TrailBlazer	Body	Lift Gate Module																																																											
T	2006	TrailBlazer	Body	Passenger Door Module																																																											
T	2006	TrailBlazer	Body	Passenger Presence System																																																											
T	2006	TrailBlazer	Body	Uplevel Radio																																																											
T	2006	TrailBlazer	Body	Navigation Radio																																																											
T	2006	TrailBlazer	Body	Rear Seat Audio																																																											
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																											
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																											
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display											V																																																
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display											V																																																
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES														V																																												
T	2006	TrailBlazer EXT	Body	Body Control Module																																																											
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																											
T	2006	TrailBlazer EXT	Body	Driver Door Module																																																											
T	2006	TrailBlazer EXT	Body	Driver Seat Module																																																											
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																											
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																											
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																											
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																											
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																																											
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																											
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																											
T	2006	TrailBlazer EXT	Body	Navigation Radio																																																											
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																											
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																											
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																											
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																											
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																											
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																											
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module									V	V																																																		
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module									V	V																																																		
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																										
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																										
T	2007	Colorado	Body	Body Control Module																																																										
T	2007	Colorado	Body	Digital Radio Receiver																																																										
T	2007	Colorado	Body	Generator Battery Control Module																																																										
T	2007	Colorado	Body	Instrument Panel Cluster																																																										
T	2007	Colorado	Body	Passenger Presence System																																																										
T	2007	Colorado	Body	Base Radio																																																										
T	2007	Colorado	Body	Uplevel Radio																																																										
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module									V	V																																																
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module											V																																														
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module									V	V																																															
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module											V																																														
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																						
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module											V																																														
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																						
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module											V																																														
T	2007	Trailblazer	Chassis	Electronic Brake Control Module														V																																											
T	2007	Trailblazer	Body	Body Control Module																																																										
T	2007	Trailblazer	Body	Digital Radio Receiver																																																										
T	2007	Trailblazer	Body	Disc Player and Video Display																																																										
T	2007	Trailblazer	Body	Driver Door Module																																																										
T	2007	Trailblazer	Body	Driver Seat Module																																																										
T	2007	Trailblazer	Body	Generator Battery Control Module																																																										
T	2007	Trailblazer	Body	HVAC Control Module Auto																																																										
T	2007	Trailblazer	Body	HVAC Control Module Manual																																																										
T	2007	Trailblazer	Body	Instrument Panel Cluster																																																										
T	2007	Trailblazer	Body	Lift Gate Module																																																										
T	2007	Trailblazer	Body	Passenger Door Module																																																										
T	2007	Trailblazer	Body	Passenger Presence System																																																										
T	2007	Trailblazer	Body	Uplevel Radio																																																										
T	2007	Trailblazer	Body	Navigation Radio																																																										
T	2007	Trailblazer	Body	Rear Seat Audio																																																										
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																										
T	2007	Trailblazer	Body	Theft Deterrent Module																																																										
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																										
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module				V					V	V																																																
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2008	Colorado	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2008	Colorado	Body	Digital Radio Receiver																																																											
T	2008	Colorado	Body	Generator Battery Control Module																																																												
T	2008	Colorado	Body	Instrument Panel Cluster																																																												
T	2008	Colorado	Body	Passenger Presence System																																																												
T	2008	Colorado	Body	Base Radio																																																												
T	2008	Colorado	Body	Uplevel Radio																																																												
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																																												
T	2008	Colorado	Body	Theft Deterrent Module																																																												
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																																												
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module				V					V	V																																																		
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module											V																																																
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																								
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module											V																																																
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																								
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module														V																																													
T	2008	TrailBlazer	Body	Body Control Module																																																												
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																												
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																												
T	2008	TrailBlazer	Body	Driver Door Module																																																												
T	2008	TrailBlazer	Body	Driver Seat Module																																																												
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																												
T	2008	TrailBlazer	Body	HVAC Control Module Auto																																																												
T	2008	TrailBlazer	Body	HVAC Control Module Manual																																																												
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																																												
T	2008	TrailBlazer	Body	Lift Gate Module																																																												
T	2008	TrailBlazer	Body	Passenger Door Module																																																												
T	2008	TrailBlazer	Body	Passenger Presence System																																																												
T	2008	TrailBlazer	Body	Uplevel Radio																																																												
T	2008	TrailBlazer	Body	Navigation Radio																																																												
T	2008	TrailBlazer	Body	Rear Seat Audio																																																												
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
T	2008	TrailBlazer	Body	Theft Deterrent Module																																																												
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																												
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																		
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																		
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module	V			V																																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																												
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																												
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																												
T	2009	Colorado	Chassis	Electronic Brake Control Module																																																												
T	2009	Colorado	Body	Body Control Module																																																												
T	2009	Colorado	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2009	Colorado	Body	Generator Battery Control Module																																																										
T	2009	Colorado	Body	Instrument Panel Cluster																																																											
T	2009	Colorado	Body	Passenger Presence System																																																										
T	2009	Colorado	Body	Base Radio																																																										
T	2009	Colorado	Body	Uplevel Radio																																																										
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2009	Colorado	Body	Theft Deterrent Module																																																										
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module				V						V																																																
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module											V																																															
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																						
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module											V																																															
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																						
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module														V																																											
T	2009	TrailBlazer	Body	Body Control Module																																																										
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																										
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2009	TrailBlazer	Body	Driver Door Module																																																										
T	2009	TrailBlazer	Body	Driver Seat Module																																																										
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																										
T	2009	TrailBlazer	Body	HVAC Control Module Auto																																																										
T	2009	TrailBlazer	Body	HVAC Control Module Manual																																																										
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2009	TrailBlazer	Body	Lift Gate Module																																																										
T	2009	TrailBlazer	Body	Passenger Door Module																																																										
T	2009	TrailBlazer	Body	Passenger Presence System																																																										
T	2009	TrailBlazer	Body	Uplevel Radio																																																										
T	2009	TrailBlazer	Body	Navigation Radio																																																										
T	2009	TrailBlazer	Body	Rear Seat Audio																																																										
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2009	TrailBlazer	Body	Theft Deterrent Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V			V																																																						
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
T	2010	ALL	Chassis	Electronic Brake Control Module																																																										
T	2010	ALL	Body	Body Control Module																																																										
T	2010	ALL	Body	Digital Radio Receiver																																																										
T	2010	ALL	Body	Generator Battery Control Module																																																										
T	2010	ALL	Body	Instrument Panel Cluster																																																										
T	2010	ALL	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2010	ALL	Body	Personal Audio Link Module																																																										
T	2010	ALL	Body	Base Radio																																																										
T	2010	ALL	Body	Uplevel Radio																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Theft Deterrent Module																																																										
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																										
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module				V					V																																																	
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module				V					V																																																	
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V			V																																																							
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
T	2011	ALL	Chassis	Electronic Brake Control Module																																																										
T	2011	ALL	Body	Body Control Module																																																									
T	2011	ALL	Body	Digital Radio Receiver																																																									
T	2011	ALL	Body	Generator Battery Control Module																																																									
T	2011	ALL	Body	Instrument Panel Cluster																																																									
T	2011	ALL	Body	Passenger Presence System																																																									
T	2011	ALL	Body	Personal Audio Link Module																																																									
T	2011	ALL	Body	Base Radio																																																									
T	2011	ALL	Body	Uplevel Radio																																																									
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2011	ALL	Body	Theft Deterrent Module																																																									
T	2011	ALL	Body	Vehicle Comm. Interface Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module				V					V																																																	
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module				V					V																																																	
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V			V																																																							
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																										
T	2012	Colorado (First Gen)	Body	Body Control Module																																																										
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																										
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																										
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																										
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																										
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																										
T	2012	Colorado (First Gen)	Body	Base Radio																																																										
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																										
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																										
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2012	Colorado (Second Gen)	Body	Body Control Module																																																										
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																										
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																										
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2012	S10	Powertrain	Transfer Case Control Module																																																										
T	2012	S10	Chassis	Electronic Brake Control Module																																																										
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2012	S10	Body	Body Control Module																																																										
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2012	S10	Body	Instrument Cluster																																																										
T	2012	S10	Body	Trailer Interface Control Module																																																										
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2013	Colorado	Powertrain	Transfer Case Control Module																																																										
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2013	Colorado	Body	Body Control Module																																																										
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	Colorado	Body	Instrument Cluster																																																										
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2013	S10	Powertrain	Transfer Case Control Module																																																										
T	2013	S10	Chassis	Electronic Brake Control Module																																																										
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2013	S10	Body	Body Control Module																																																										
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	S10	Body	Instrument Cluster																																																										
T	2013	S10	Body	Trailer Interface Control Module																																																										
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																										
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2013	Trailblazer	Body	Body Control Module																																																										
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	Trailblazer	Body	Instrument Cluster																																																										
T	2013	Trailblazer	Body	Trailer Interface Control Module																																																										
T	2013	Trailblazer	Body	Parking Assist Control Module																																																										
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2014	Colorado	Powertrain	Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	Colorado	Body	Body Control Module																																																										
T	2014	Colorado	Body	Body Control Module																																																										
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Colorado	Body	Instrument Cluster																																																										
T	2014	Colorado	Body	Radio																																																										
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																										
T	2014	Colorado	Body	Parking Assist Control Module																																																										
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2014	S10	Powertrain	Transfer Case Control Module																																																										
T	2014	S10	Chassis	Electronic Brake Control Module																																																										
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	S10	Body	Body Control Module																																																										
T	2014	S10	Body	Body Control Module																																																										
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	S10	Body	Instrument Cluster																																																										
T	2014	S10	Body	Trailer Interface Control Module																																																										
T	2014	S10	Body	Radio																																																										
T	2014	S10	Body	Parking Assist Control Module																																																										
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																										
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	Trailblazer	Body	Body Control Module																																																										
T	2014	Trailblazer	Body	Body Control Module																																																										
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Trailblazer	Body	Instrument Cluster																																																										
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																										
T	2014	Trailblazer	Body	Parking Assist Control Module																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2015	Colorado	Powertrain	Chassis Control Module																																																									
T	2015	Colorado	Powertrain	Transfer Case Control Module																																																									
T	2015	Colorado	Chassis	Electronic Brake Control Module																																																									
T	2015	Colorado	Chassis	Power Steering Control Module																																																									
T	2015	Colorado	Body	Body Control Module																																																									
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Colorado	Body	Passenger Presence Module																																																									
T	2015	Colorado	Body	Radio																																																									
T	2015	Colorado	Body	Amplifier																																																									
T	2015	Colorado	Body	Human Machine Interface Control Module																																																									
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																																									
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																									
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																									
T	2015	Colorado	Body	Frontview Camera Module																																																									
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																									
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																									
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2015	Colorado (MMM)	Body	Body Control Module																																																									
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Colorado (MMM)	Body	Instrument Cluster																																																									
T	2015	Colorado (MMM)	Body	Radio																																																									
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																									
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																									
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2015	S10	Powertrain	Transfer Case Control Module																																																											
T	2015	S10	Chassis	Electronic Brake Control Module																																																											
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2015	S10	Body	Body Control Module																																																											
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2015	S10	Body	Instrument Cluster																																																											
T	2015	S10	Body	Trailer Interface Control Module																																																											
T	2015	S10	Body	Radio																																																											
T	2015	S10	Body	Telematics Communication Interface Control Module																																																											
T	2015	S10	Body	Parking Assist Control Module																																																											
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																											
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																											
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2015	Trailblazer	Body	Body Control Module																																																											
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2015	Trailblazer	Body	Instrument Cluster																																																											
T	2015	Trailblazer	Body	Trailer Interface Control Module																																																											
T	2015	Trailblazer	Body	Radio																																																											
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																											
T	2015	Trailblazer	Body	Parking Assist Control Module																																																											
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																											
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																											
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																											
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																											
T	2016	Colorado (1GC)	Body	Body Control Module																																																											
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																																											
T	2016	Colorado (1GC)	Body	Radio Controls																																																											
T	2016	Colorado (1GC)	Body	HVAC Controls																																																											
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																											
T	2016	Colorado (1GC)	Body	Radio																																																											
T	2016	Colorado (1GC)	Body	Amplifier																																																											
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																										
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																										
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																										
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																										
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																										
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																										
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2016	Colorado (MMM)	Body	Body Control Module																																																										
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																										
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																										
T	2016	Colorado (MMM)	Body	Radio																																																										
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																										
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																										
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																										
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																										
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
T	2016	S10	Powertrain	Transfer Case Control Module																																																										
T	2016	S10	Chassis	Electronic Brake Control Module																																																										
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2016	S10	Body	Body Control Module																																																									
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	S10	Body	Instrument Cluster																																																									
T	2016	S10	Body	Trailer Interface Control Module																																																									
T	2016	S10	Body	Radio																																																									
T	2016	S10	Body	Telematics Communication Interface Control Module																																																										
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																										
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																										
T	2016	S10	Body	Parking Assist Control Module																																																										
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																										
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2016	Trailblazer	Body	Body Control Module																																																										
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Trailblazer	Body	Instrument Cluster																																																										
T	2016	Trailblazer	Body	Trailer Interface Control Module																																																										
T	2016	Trailblazer	Body	Radio																																																										
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																										
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																										
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																										
T	2016	Trailblazer	Body	Parking Assist Control Module																																																										
V	2009	ALL	Powertrain	Engine Control Module				V					V																																																	
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2009	ALL	Powertrain	Rear Drive System																																																										
V	2009	ALL	Powertrain	Transmission Control Module		V																																																								
V	2009	ALL	Chassis	Electronic Brake Control Module													V																																													
V	2009	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
V	2009	ALL	Body	Digital Radio Receiver																																																										
V	2009	ALL	Body	Driver Door Switch																																																										
V	2009	ALL	Body	Heated Seat Module																															V	V																										
V	2009	ALL	Body	HVAC Control Module Auto																												V	V																													
V	2009	ALL	Body	HVAC Control Module Manual																													V																													
V	2009	ALL	Body	Instrument Panel Cluster																																																										
V	2009	ALL	Body	Lift Gate Module																																																										
V	2009	ALL	Body	Park Assist Module																																							V	V	V																	
V	2009	ALL	Body	Passenger Door Switch																																																										
V	2009	ALL	Body	Passenger Presence System																																										V																
V	2009	ALL	Body	Radio																																																										
V	2009	ALL	Body	Rear HVAC/RSA																																																										
V	2009	ALL	Body	Rollover Sensor																																																										
V	2009	ALL	Body	Supplemental Inflatable Restraint																																										V									V							
V	2009	ALL	Body	Theft Deterrent Module																																																										
V	2010	ALL	Powertrain	Engine Control Module				V																																																						
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2010	ALL	Powertrain	Rear Drive System																																																										
V	2010	ALL	Powertrain	Transmission Control Module		V																																																								
V	2010	ALL	Chassis	Electronic Brake Control Module													V																																													
V	2010	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
V	2010	ALL	Body	Digital Radio Receiver																																																										
V	2010	ALL	Body	Driver Door Switch																																																										
V	2010	ALL	Body	Heated Seat Module																															V	V																										
V	2010	ALL	Body	HVAC Control Module Auto																												V	V																													
V	2010	ALL	Body	HVAC Control Module Manual																													V																													
V	2010	ALL	Body	Instrument Panel Cluster																																																										
V	2010	ALL	Body	Lift Gate Module																																																										
V	2010	ALL	Body	Park Assist Module																																							V	V	V																	

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
V	2010	ALL	Body	Passenger Door Switch																																																								
V	2010	ALL	Body	Passenger Presence System																																									V															
V	2010	ALL	Body	Radio																																																							
V	2010	ALL	Body	Rear HVAC/RSA																																																							
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																							
V	2010	ALL	Body	Theft Deterrent Module																																																							
V	2011	ALL	Powertrain	Engine Control Module				V																																																			
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																							
V	2011	ALL	Powertrain	Rear Drive System																																																							
V	2011	ALL	Powertrain	Transmission Control Module		V																																																					
V	2011	ALL	Chassis	Electronic Brake Control Module													V																																										
V	2011	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																													
V	2011	ALL	Body	Digital Radio Receiver																																																							
V	2011	ALL	Body	Driver Door Switch																																																							
V	2011	ALL	Body	Heated Seat Module																														V	V																									
V	2011	ALL	Body	HVAC Control Module Auto																												V	V																											
V	2011	ALL	Body	HVAC Control Module Manual																													V																											
V	2011	ALL	Body	Instrument Panel Cluster																																																							
V	2011	ALL	Body	Lift Gate Module																																																							
V	2011	ALL	Body	Park Assist Module																																							V	V	V															
V	2011	ALL	Body	Passenger Door Switch																																																							
V	2011	ALL	Body	Passenger Presence System																																									V															
V	2011	ALL	Body	Radio																																																							
V	2011	ALL	Body	Rear HVAC/RSA																																																							
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																							
V	2011	ALL	Body	Theft Deterrent Module																																																							
V	2012	ALL	Powertrain	Engine Control Module	V			V					V																																														
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																							
V	2012	ALL	Powertrain	Rear Drive System																																																							
V	2012	ALL	Powertrain	Transmission Control Module		V																																																					
V	2012	ALL	Chassis	Electronic Brake Control Module													V																																										
V	2012	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																													
V	2012	ALL	Body	Digital Radio Receiver																																																							
V	2012	ALL	Body	Driver Door Switch																																																							
V	2012	ALL	Body	Heated Seat Module																														V	V																									
V	2012	ALL	Body	HVAC Control Module Auto																												V	V																											
V	2012	ALL	Body	HVAC Control Module Manual																													V																											
V	2012	ALL	Body	Instrument Panel Cluster																																																							
V	2012	ALL	Body	Lift Gate Module																																																							
V	2012	ALL	Body	Park Assist Module																																							V	V	V															
V	2012	ALL	Body	Passenger Door Switch																																																							
V	2012	ALL	Body	Passenger Presence System																																									V															
V	2012	ALL	Body	Radio																																																							
V	2012	ALL	Body	Rear HVAC/RSA																																																							
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																							
V	2012	ALL	Body	Theft Deterrent Module																																																							
V	2013	ALL	Powertrain	Engine Control Module	V			V					V																																														
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																							
V	2013	ALL	Powertrain	Rear Drive System																																																							
V	2013	ALL	Powertrain	Transmission Control Module		V																																																					
V	2013	ALL	Chassis	Electronic Brake Control Module													V																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
V	2013	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
V	2013	ALL	Body	Digital Radio Receiver																																																									
V	2013	ALL	Body	Driver Door Switch																																																									
V	2013	ALL	Body	Heated Seat Module																														V	V																											
V	2013	ALL	Body	HVAC Control Module Auto																												V	V																													
V	2013	ALL	Body	HVAC Control Module Manual																													V																													
V	2013	ALL	Body	Instrument Panel Cluster																																																									
V	2013	ALL	Body	Left Side Object Detection Module																																																									
V	2013	ALL	Body	Lift Gate Module																																																									
V	2013	ALL	Body	Park Assist Module																																							V	V	V																	
V	2013	ALL	Body	Passenger Door Switch																																																									
V	2013	ALL	Body	Passenger Presence System																																									V																
V	2013	ALL	Body	Radio																																																									
V	2013	ALL	Body	Rear HVAC/RSA																																																									
V	2013	ALL	Body	Right Side Object Detection Module																																																									
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2013	ALL	Body	Theft Deterrent Module																																																									
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2014	Traverse	Powertrain	Chassis Control Module																																																									
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																									
V	2014	Traverse	Chassis	Electronic Brake Control Module																																																									
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																									
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2014	Traverse	Body	Passenger Presence Module																																																									
V	2014	Traverse	Body	Instrument Cluster																																																									
V	2014	Traverse	Body	Radio																																																									
V	2014	Traverse	Body	Rear Audio Control Module																																																									
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																									
V	2014	Traverse	Body	Personal Audio Link Control Module																																																									
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																									
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																									
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																									
V	2014	Traverse	Body	Liftgate Control Module																																																									
V	2014	Traverse	Body	Seat Memory Control Module																																																									
V	2014	Traverse	Body	Front Seat Heating Control Module																																																									
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																									
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																									
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																									
V	2014	Traverse	Body	Parking Assist Control Module																																																									
V	2014	Traverse	Body	Frontview Camera Module																																																									
V	2014	Traverse	Body	Theft Deterrent Module																																																									
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																									
V	2015	Traverse	Chassis	Electronic Brake Control Module																																																									
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
V	2015	Traverse	Body	Passenger Presence Module																																																											
V	2015	Traverse	Body	Instrument Cluster																																																										
V	2015	Traverse	Body	Radio																																																										
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2015	Traverse	Body	Liftgate Control Module																																																										
V	2015	Traverse	Body	Seat Memory Control Module																																																										
V	2015	Traverse	Body	Front Seat Heating Control Module																																																										
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2015	Traverse	Body	Parking Assist Control Module																																																										
V	2015	Traverse	Body	Frontview Camera Module																																																										
V	2015	Traverse	Body	Theft Deterrent Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Traverse	Chassis	Electronic Brake Control Module																																																										
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Traverse	Body	Passenger Presence Module																																																										
V	2016	Traverse	Body	Instrument Cluster																																																										
V	2016	Traverse	Body	Radio																																																										
V	2016	Traverse	Body	Rear Audio Control Module																																																										
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2016	Traverse	Body	Personal Audio Link Control Module																																																										
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																										
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Liftgate Control Module																																																										
V	2016	Traverse	Body	Seat Memory Control Module																																																										
V	2016	Traverse	Body	Front Seat Heating Control Module																																																										
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2016	Traverse	Body	Parking Assist Control Module																																																										
V	2016	Traverse	Body	Frontview Camera Module																																																										
V	2016	Traverse	Body	Theft Deterrent Module																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2011	Orlando	Chassis	Parking Brake Control Module																																																										
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2011	Orlando	Chassis	Power Steering Control Module																																																										
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2011	Orlando	Body	Body Control Module																																																										
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2011	Orlando	Body	Instrument Cluster																																																										
A	2011	Orlando	Body	Trailer Interface Control Module																																																										
A	2011	Orlando	Body	Radio																																																										
A	2011	Orlando	Body	Multimedia Player Interface Module																																																										
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
A	2011	Orlando	Body	Keyless Entry Control Module																																																										
A	2011	Orlando	Body	Parking Assist Control Module																																																										
A	2011	Orlando	Body	Steering Column Lock Control Module																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																										
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2012	Orlando	Chassis	Parking Brake Control Module																																																										
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2012	Orlando	Chassis	Power Steering Control Module																																																										
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2012	Orlando	Body	Body Control Module																																																										
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2012	Orlando	Body	Instrument Cluster																																																										
A	2012	Orlando	Body	Trailer Interface Control Module																																																										
A	2012	Orlando	Body	Radio																																																										
A	2012	Orlando	Body	Multimedia Player Interface Module																																																										
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
A	2012	Orlando	Body	Keyless Entry Control Module																																																										
A	2012	Orlando	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2012	Orlando	Body	Steering Column Lock Control Module																																																										
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V																																																									
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V																																																									
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																										
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2013	Orlando	Chassis	Parking Brake Control Module																																																										
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Orlando	Chassis	Power Steering Control Module																																																										
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	Orlando	Body	Body Control Module																																																										
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	Orlando	Body	Instrument Cluster																																																										
A	2013	Orlando	Body	Radio																																																										
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2013	Orlando	Body	Multimedia Player Interface Module																																																										
A	2013	Orlando	Body	Mobile Telephone Control Module																																																										
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2013	Orlando	Body	Front Seat Heating Control Module																																																										
A	2013	Orlando	Body	Keyless Entry Control Module																																																										
A	2013	Orlando	Body	Parking Assist Control Module																																																										
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																																																									
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																																																									
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V																																																									
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V																																																									
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	Orlando	Chassis	Power Steering Control Module																																																										
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	Orlando	Body	Body Control Module																																																										
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	Orlando	Body	Instrument Cluster																																																										
A	2014	Orlando	Body	Radio																																																										
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2014	Orlando	Body	Multimedia Player Interface Module																																																										
A	2014	Orlando	Body	Mobile Telephone Control Module																																																										
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2014	Orlando	Body	Front Seat Heating Control Module																																																										
A	2014	Orlando	Body	Rear Seat Heating Control Module																																																										
A	2014	Orlando	Body	Keyless Entry Control Module																																																										
A	2014	Orlando	Body	Parking Assist Control Module																																																										
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																																																									
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																																																									
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	Orlando	Chassis	Power Steering Control Module																																																										
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	Orlando	Body	Body Control Module																																																										
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	Orlando	Body	Instrument Cluster																																																										
A	2015	Orlando	Body	Radio																																																										
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2015	Orlando	Body	Mobile Telephone Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																										
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2015	Orlando	Body	Front Seat Heating Control Module																																																										
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																										
A	2015	Orlando	Body	Keyless Entry Control Module																																																										
A	2015	Orlando	Body	Parking Assist Control Module																																																										
A	2015	Orlando	Body	Frontview Camera Module																																																										
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																																																									
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																																																									
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																										
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																										
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2016	Orlando	Chassis	Power Steering Control Module																																																										
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	Orlando	Body	Body Control Module																																																										
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	Orlando	Body	Instrument Cluster																																																										
A	2016	Orlando	Body	Radio																																																										
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2016	Orlando	Body	Multimedia Player Interface Module																																																										
A	2016	Orlando	Body	Mobile Telephone Control Module																																																										
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																										
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2016	Orlando	Body	Front Seat Heating Control Module																																																										
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																										
A	2016	Orlando	Body	Keyless Entry Control Module																																																										
A	2016	Orlando	Body	Parking Assist Control Module																																																										
A	2016	Orlando	Body	Frontview Camera Module																																																										
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																																																											
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																											
C	2009	N200	Chassis	Electronic Brake Control Module																																																											
C	2009	N200	Body	Supplemental Inflatable Restraint																																																											
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																											
C	2009	N300	Chassis	Electronic Brake Control Module																																																											
C	2009	N300	Body	Supplemental Inflatable Restraint																																																											
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																											
C	2010	N200	Chassis	Electronic Brake Control Module																																																											
C	2010	N200	Body	Supplemental Inflatable Restraint																																																											
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																											
C	2010	N300	Chassis	Electronic Brake Control Module																																																											
C	2010	N300	Body	Supplemental Inflatable Restraint																																																											
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																											
C	2011	N200	Chassis	Electronic Brake Control Module																																																											
C	2011	N200	Body	Supplemental Inflatable Restraint																																																											
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																											
C	2011	N300	Chassis	Electronic Brake Control Module																																																											
C	2011	N300	Body	Supplemental Inflatable Restraint																																																											
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																											
C	2012	N200	Chassis	Electronic Brake Control Module																																																											
C	2012	N200	Body	Supplemental Inflatable Restraint																																																											
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																											
C	2012	N300	Chassis	Electronic Brake Control Module																																																											
C	2012	N300	Body	Supplemental Inflatable Restraint																																																											
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module																																																											
C	2013	N300	Chassis	Electronic Brake Control Module																																																											
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module																																																											
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																																											
C	2014	N300	Chassis	Electronic Brake Control Module																																																											
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module																																																											
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																																											
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																																											
C	2015	Max	Chassis	Electronic Brake Control Module																																																											
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module																																																											
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																																											
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																																											
C	2015	Move	Chassis	Electronic Brake Control Module																																																											
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module																																																											
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																																											
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																																											
C	2015	N300	Chassis	Electronic Brake Control Module																																																											
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module																																																											
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																																											
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																																											
C	2016	Max	Chassis	Electronic Brake Control Module																																																											
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module																																																											
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																																											
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																																											
C	2016	Move	Chassis	Electronic Brake Control Module																																																											
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module																																																											
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																																											
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																																											
C	2016	N300	Chassis	Electronic Brake Control Module																																																											
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																											
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																											
M	2015	City Express	Chassis	Electronic Brake Control Module																																																											
M	2015	City Express	Chassis	Power Steering Control Module																																																											
M	2015	City Express	Body	Body Control Module																																																										
M	2015	City Express	Body	Underhood Fuse Block																																																										
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	City Express	Body	Instrument Cluster																																																										
M	2015	City Express	Body	Tire Pressure Indicator Module																																																											
M	2015	City Express	Body	Radio																																																										
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																											
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																											
M	2016	City Express	Chassis	Electronic Brake Control Module																																																											
M	2016	City Express	Chassis	Power Steering Control Module																																																											
M	2016	City Express	Body	Body Control Module																																																										
M	2016	City Express	Body	Underhood Fuse Block																																																										
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2016	City Express	Body	Instrument Cluster																																																										
M	2016	City Express	Body	Tire Pressure Indicator Module																																																											
M	2016	City Express	Body	Radio																																																										
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2011	Orlando	Chassis	Parking Brake Control Module																																																											
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2011	Orlando	Chassis	Power Steering Control Module																																																											
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
P	2011	Orlando	Body	Body Control Module																																																										
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2011	Orlando	Body	Instrument Cluster																																																										
P	2011	Orlando	Body	Trailer Interface Control Module																																																										
P	2011	Orlando	Body	Radio																																																										
P	2011	Orlando	Body	Multimedia Player Interface Module																																																										
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
P	2011	Orlando	Body	Keyless Entry Control Module																																																										
P	2011	Orlando	Body	Parking Assist Control Module																																																										
P	2011	Orlando	Body	Steering Column Lock Control Module																																																										
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																										
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																										
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																										
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																										
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2012	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2012	Orlando	Chassis	Parking Brake Control Module																																																										
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2012	Orlando	Chassis	Power Steering Control Module																																																										
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2012	Orlando	Body	Body Control Module																																																										
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2012	Orlando	Body	Instrument Cluster																																																										
P	2012	Orlando	Body	Trailer Interface Control Module																																																										
P	2012	Orlando	Body	Radio																																																										
P	2012	Orlando	Body	Multimedia Player Interface Module																																																										
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
P	2012	Orlando	Body	Keyless Entry Control Module																																																										
P	2012	Orlando	Body	Parking Assist Control Module																																																										
P	2012	Orlando	Body	Steering Column Lock Control Module																																																										
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V																																																									
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V																																																									
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																											
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																											
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																											
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																											
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2013	Orlando	Chassis	Parking Brake Control Module																																																											
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2013	Orlando	Chassis	Power Steering Control Module																																																											
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2013	Orlando	Body	Body Control Module																																																											
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2013	Orlando	Body	Instrument Cluster																																																											
P	2013	Orlando	Body	Radio																																																											
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																											
P	2013	Orlando	Body	Multimedia Player Interface Module																																																											
P	2013	Orlando	Body	Mobile Telephone Control Module																																																											
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																											
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																											
P	2013	Orlando	Body	Front Seat Heating Control Module																																																											
P	2013	Orlando	Body	Keyless Entry Control Module																																																											
P	2013	Orlando	Body	Parking Assist Control Module																																																											
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission	V																																																										
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission	V																																																										
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission	V																																																										
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission	V																																																										
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
P	2014	Orlando	Chassis	Power Steering Control Module																																																										
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2014	Orlando	Body	Body Control Module																																																										
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2014	Orlando	Body	Instrument Cluster																																																										
P	2014	Orlando	Body	Radio																																																										
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																										
P	2014	Orlando	Body	Multimedia Player Interface Module																																																										
P	2014	Orlando	Body	Mobile Telephone Control Module																																																										
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
P	2014	Orlando	Body	Front Seat Heating Control Module																																																										
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																										
P	2014	Orlando	Body	Keyless Entry Control Module																																																										
P	2014	Orlando	Body	Parking Assist Control Module																																																										
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																																																									
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																																																									
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2015	Orlando	Chassis	Power Steering Control Module																																																										
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2015	Orlando	Body	Body Control Module																																																										
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2015	Orlando	Body	Instrument Cluster																																																										
P	2015	Orlando	Body	Radio																																																										
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																										
P	2015	Orlando	Body	Mobile Telephone Control Module																																																										
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																										
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
P	2015	Orlando	Body	Front Seat Heating Control Module																																																										
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																										
P	2015	Orlando	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
P	2015	Orlando	Body	Parking Assist Control Module																																																										
P	2015	Orlando	Body	Frontview Camera Module																																																											
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission	V																																																										
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission	V																																																										
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																												
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																												
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																												
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																												
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																												
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																												
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																												
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2016	Orlando	Chassis	Power Steering Control Module																																																												
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2016	Orlando	Body	Body Control Module																																																												
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2016	Orlando	Body	Instrument Cluster																																																												
P	2016	Orlando	Body	Radio																																																												
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																												
P	2016	Orlando	Body	Multimedia Player Interface Module																																																												
P	2016	Orlando	Body	Mobile Telephone Control Module																																																												
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																																												
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																												
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																												
P	2016	Orlando	Body	Front Seat Heating Control Module																																																												
P	2016	Orlando	Body	Rear Seat Heating Control Module																																																												
P	2016	Orlando	Body	Keyless Entry Control Module																																																												
P	2016	Orlando	Body	Parking Assist Control Module																																																												
P	2016	Orlando	Body	Frontview Camera Module																																																												
U	2004	ALL	Powertrain	Engine Control Module																																																												
U	2004	ALL	Powertrain	Transmission Control Module																																																												
U	2004	ALL	Body	Digital Radio Receiver																																																												
U	2004	ALL	Body	Driver Information Center																																																											
U	2004	ALL	Body	Instrument Panel Cluster																																																												
U	2004	ALL	Body	Radio																																																												
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
U	2004	ALL	Body	Vehicle Theft Deterrent																																																												
U	2005	ALL	Powertrain	Engine Control Module																																																												
U	2005	ALL	Powertrain	Transmission Control Module																																																												
U	2005	ALL	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
U	2005	ALL	Body	Body Control Module																																																										
U	2005	ALL	Body	Disc Player and Video																																																										
U	2005	ALL	Body	Digital Radio Receiver																																																										
U	2005	ALL	Body	HVAC Control Module																											V																																
U	2005	ALL	Body	Instrument Panel Cluster																																																										
U	2005	ALL	Body	Left Power Sliding Door Module																																																										
U	2005	ALL	Body	Mobile Digital Media																																																										
U	2005	ALL	Body	Navigation Radio																																																										
U	2005	ALL	Body	Navigation Radio																																																										
U	2005	ALL	Body	Radio																																																							V		
U	2005	ALL	Body	Right Power Sliding Door Module																																																										
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																										
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module	V								V																																																	
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																										
U	2006	ALL	Chassis	Electronic Brake Control Module																																																										
U	2006	ALL	Body	Body Control Module																																																										
U	2006	ALL	Body	Disc Player and Video																																																										
U	2006	ALL	Body	Digital Radio Receiver																																																										
U	2006	ALL	Body	HVAC Control Module																											V																																
U	2006	ALL	Body	Instrument Panel Cluster																																																										
U	2006	ALL	Body	Left Power Sliding Door Module																																																										
U	2006	ALL	Body	Mobile Digital Media																																																										
U	2006	ALL	Body	Navigation Radio																																																										
U	2006	ALL	Body	Navigation Radio																																																										
U	2006	ALL	Body	Radio																																																						V		
U	2006	ALL	Body	Right Power Sliding Door Module																																																										
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module	V																																																										
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V																																																										
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
U	2007	ALL	Chassis	Electronic Brake Control Module																																																										
U	2007	ALL	Body	Body Control Module																																																										
U	2007	ALL	Body	Digital Radio Receiver																																																										
U	2007	ALL	Body	Disc Player and Video Display																																																										
U	2007	ALL	Body	HVAC Control Module																											V																																
U	2007	ALL	Body	Left Power Sliding Door Module																																																										
U	2007	ALL	Body	Mobile Digital Media																																																										
U	2007	ALL	Body	Radio																																																						V		
U	2007	ALL	Body	Navigation Radio																																																										
U	2007	ALL	Body	Right Power Sliding Door Module																																																										
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module	V																																																									
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V																																																									
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
U	2008	ALL	Chassis	Electronic Brake Control Module																																																										
U	2008	ALL	Body	Body Control Module																																																										
U	2008	ALL	Body	Digital Radio Receiver																																																										
U	2008	ALL	Body	Disc Player and Video Display																																																										
U	2008	ALL	Body	C60 Single Zone HVAC Manual																											V																																

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																											V																														
U	2008	ALL	Body	Left Power Sliding Door Module																																																										
U	2008	ALL	Body	Radio																																																									
U	2008	ALL	Body	Navigation Radio																																																									
U	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
U	2008	ALL	Body	Right Power Sliding Door Module																																																										
U	2009	ALL	Powertrain	Engine Control Module	V																																																									
U	2009	ALL	Powertrain	Transmission Control Module																																																										
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																										
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																										
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																										
U	2009	ALL	Body	Body Control Module																																																										
U	2009	ALL	Body	Digital Radio Receiver																																																										
U	2009	ALL	Body	Disc Player and Video Display																																																										
U	2009	ALL	Body	C60 Single Zone HVAC Manual																											V																																
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																											V																																
U	2009	ALL	Body	Instrument Panel Cluster																																																										
U	2009	ALL	Body	Left Power Sliding Door Module																																																										
U	2009	ALL	Body	Radio																																																										
U	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
U	2009	ALL	Body	Right Power Sliding Door Module																																																										
V	2004	ALL	Powertrain	Engine Data Display																																																										
V	2004	ALL	Powertrain	Transmission Data Display																																																										
V	2004	ALL	Body	Digital Radio Receiver																																																										
V	2004	ALL	Body	Driver Information Center																																																										
V	2004	ALL	Body	Instrument Panel Cluster																																																										
V	2004	ALL	Body	Radio																																																										
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2004	ALL	Body	Vehicle Theft Deterrent																																																										
V	2005	Venture	Powertrain	Engine Control Module																																																										
V	2005	Venture	Powertrain	Transmission Control Module																																																										
V	2005	Venture	Body	Digital Radio Receiver																																																										
V	2005	Venture	Body	Driver Information Center																																																										
V	2005	Venture	Body	Instrument Panel Cluster																																																										
V	2005	Venture	Body	Radio																																																										
V	2005	Venture	Body	Supplemental Inflatable Restraint																																																										
V	2005	Venture	Body	Vehicle Theft Deterrent																																																										
V	2005	Uplander	Powertrain	Engine Control Module																																																										
V	2005	Uplander	Powertrain	Transmission Control Module																																																										
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																										
V	2005	Uplander	Body	Body Control Module																																																										
V	2005	Uplander	Body	Disc Player and Video																																																										
V	2005	Uplander	Body	Digital Radio Receiver																																																										
V	2005	Uplander	Body	HVAC Control Module																											V																																
V	2005	Uplander	Body	Instrument Panel Cluster																																																										
V	2005	Uplander	Body	Left Power Sliding Door Module																																																										
V	2005	Uplander	Body	Mobile Digital Media																																																										
V	2005	Uplander	Body	Navigation Radio																																																										
V	2005	Uplander	Body	Navigation Radio																																																										
V	2005	Uplander	Body	Radio																																																							V			
V	2005	Uplander	Body	Right Power Sliding Door Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
V	2005	Uplander	Body	Supplemental Inflatable Restraint																																																										
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																											
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																											
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module	V								V																																																		
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																											
V	2006	ALL	Chassis	Electronic Brake Control Module																																																												
V	2006	ALL	Body	Body Control Module																																																											
V	2006	ALL	Body	Disc Player and Video																																																											
V	2006	ALL	Body	Digital Radio Receiver																																																											
V	2006	ALL	Body	HVAC Control Module																											V																																	
V	2006	ALL	Body	Instrument Panel Cluster																																																											
V	2006	ALL	Body	Left Power Sliding Door Module																																																											
V	2006	ALL	Body	Mobile Digital Media																																																											
V	2006	ALL	Body	Navigation Radio																																																											
V	2006	ALL	Body	Navigation Radio																																																											
V	2006	ALL	Body	Radio																																																						V			
V	2006	ALL	Body	Right Power Sliding Door Module																																																											
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module	V																																																										
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																											
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V																																																										
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																											
V	2007	ALL	Chassis	Electronic Brake Control Module																																																											
V	2007	ALL	Body	Body Control Module																																																											
V	2007	ALL	Body	Digital Radio Receiver																																																											
V	2007	ALL	Body	Disc Player and Video Display																																																											
V	2007	ALL	Body	HVAC Control Module																											V																																	
V	2007	ALL	Body	Left Power Sliding Door Module																																																											
V	2007	ALL	Body	Mobile Digital Media																																																											
V	2007	ALL	Body	Radio																																																					V			
V	2007	ALL	Body	Navigation Radio																																																										
V	2007	ALL	Body	Right Power Sliding Door Module																																																											
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module	V																																																										
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																											
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module	V																																																										
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																											
V	2008	ALL	Chassis	Electronic Brake Control Module																																																											
V	2008	ALL	Body	Body Control Module																																																											
V	2008	ALL	Body	Digital Radio Receiver																																																											
V	2008	ALL	Body	Disc Player and Video Display																																																											
V	2008	ALL	Body	C60 Single Zone HVAC Manual																											V																																	
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																											V																																	
V	2008	ALL	Body	Left Power Sliding Door Module																																																											
V	2008	ALL	Body	Radio																																																										
V	2008	ALL	Body	Navigation Radio																																																											
V	2008	ALL	Body	Remote Control Door Lock Receiver																																																											
V	2008	ALL	Body	Right Power Sliding Door Module																																																											
V	2009	ALL	Powertrain	Engine Control Module	V																																																											
V	2009	ALL	Powertrain	Transmission Control Module																																																											
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																											
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																											
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
V	2009	ALL	Body	Body Control Module																																																										
V	2009	ALL	Body	Digital Radio Receiver																																																										
V	2009	ALL	Body	Disc Player and Video Display																																																										
V	2009	ALL	Body	C60 Single Zone HVAC Manual																											V																																
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																											V																																
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																										
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																										
V	2009	ALL	Body	Left Power Sliding Door Module																																																										
V	2009	ALL	Body	Radio																																																										
V	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
V	2009	ALL	Body	Right Power Sliding Door Module																																																										
X	2004	ALL	Powertrain	Engine Control Module																																																										
X	2004	ALL	Powertrain	Transmission Control Module																																																										
X	2004	ALL	Body	Digital Radio Receiver																																																										
X	2004	ALL	Body	Driver Information Center																																																										
X	2004	ALL	Body	Instrument Panel Cluster																																																										
X	2004	ALL	Body	Radio																																																										
X	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
X	2004	ALL	Body	Vehicle Theft Deterrent																																																										
X	2005	ALL	Powertrain	Engine Control Module																																																										
X	2005	ALL	Powertrain	Transmission Control Module																																																										
X	2005	ALL	Chassis	Electronic Brake Control Module																																																										
X	2005	ALL	Body	Body Control Module																																																										
X	2005	ALL	Body	Disc Player and Video																																																										
X	2005	ALL	Body	Digital Radio Receiver																																																										
X	2005	ALL	Body	HVAC Control Module																											V																																
X	2005	ALL	Body	Instrument Panel Cluster																																																										
X	2005	ALL	Body	Left Power Sliding Door Module																																																										
X	2005	ALL	Body	Mobile Digital Media																																																										
X	2005	ALL	Body	Navigation Radio																																																										
X	2005	ALL	Body	Navigation Radio																																																										
X	2005	ALL	Body	Radio																																																						V			
X	2005	ALL	Body	Right Power Sliding Door Module																																																										
X	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																										
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
X	2006	ALL	Chassis	Electronic Brake Control Module																																																										
X	2006	ALL	Body	Body Control Module																																																										
X	2006	ALL	Body	Disc Player and Video																																																										
X	2006	ALL	Body	Digital Radio Receiver																																																										
X	2006	ALL	Body	HVAC Control Module																											V																																
X	2006	ALL	Body	Instrument Panel Cluster																																																										
X	2006	ALL	Body	Left Power Sliding Door Module																																																										
X	2006	ALL	Body	Mobile Digital Media																																																										
X	2006	ALL	Body	Navigation Radio																																																										
X	2006	ALL	Body	Navigation Radio																																																										
X	2006	ALL	Body	Radio																																																						V			
X	2006	ALL	Body	Right Power Sliding Door Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																												
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																												
A	2006	ALL	Powertrain	Transmission Control Module																																																												
A	2006	ALL	Chassis	Electronic Brake Control Module																																																												
A	2006	ALL	Chassis	Power Steering Control Module																																																												
A	2006	ALL	Body	Body Control Module																																																												
A	2006	ALL	Body	Digital Radio Receiver																																																												
A	2006	ALL	Body	Instrument Panel Cluster																																																												
A	2006	ALL	Body	Radio																																																												
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
A	2006	ALL	Body	Theft Deterrent Module																																																												
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																												
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																												
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																												
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																												
A	2007	ALL	Chassis	Electronic Brake Control Module																																																												
A	2007	ALL	Chassis	Power Steering Control Module																																																												
A	2007	ALL	Body	Body Control Module																																																												
A	2007	ALL	Body	Digital Radio Receiver																																																												
A	2007	ALL	Body	Instrument Panel Cluster																																																												
A	2007	ALL	Body	Radio																																																												
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
A	2007	ALL	Body	Theft Deterrent Module																																																												
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																												
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																												
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																												
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																												
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																												
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																												
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES																																																												
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2008	HHR	Chassis	Power Steering Control Module																																																												
A	2008	HHR	Chassis	Power Steering Control Module																																																												
A	2008	HHR	Body	Body Control Module																																																												
A	2008	HHR	Body	Digital Radio Receiver																																																												
A	2008	HHR	Body	Instrument Panel Cluster																																																												
A	2008	HHR	Body	Radio																																																												
A	2008	HHR	Body	Supplemental Inflatable Restraint																																																												
A	2008	HHR	Body	Theft Deterrent Module																																																												
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																												
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																												
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																												
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																												
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																												
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																												
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																												
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2008	HHR Panel	Body	Body Control Module																																																												
A	2008	HHR Panel	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																														
A	2008	HHR Panel	Body	Radio																																																														
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																																														
A	2008	HHR Panel	Body	Theft Deterrent Module																																																														
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																																														
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																																														
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																														
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																														
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module										V																																																			
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																														
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module										V																																																				
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																														
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																																														
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																																														
A	2009	HHR	Chassis	Power Steering Control Module																																																														
A	2009	HHR	Chassis	Power Steering Control Module																																																														
A	2009	HHR	Body	Body Control Module																																																														
A	2009	HHR	Body	Digital Radio Receiver																																																														
A	2009	HHR	Body	Instrument Panel Cluster																																																														
A	2009	HHR	Body	Radio																																																														
A	2009	HHR	Body	Supplemental Inflatable Restraint																																																														
A	2009	HHR	Body	Theft Deterrent Module																																																														
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																														
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																														
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module										V																																																			
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																														
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module										V																																																			
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																														
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																														
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																														
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																														
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																														
A	2009	HHR Panel	Body	Body Control Module																																																														
A	2009	HHR Panel	Body	Digital Radio Receiver																																																														
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																														
A	2009	HHR Panel	Body	Radio																																																														
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																																														
A	2009	HHR Panel	Body	Theft Deterrent Module																																																														
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																														
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																														
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module										V																																																			
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																														
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module										V																																																			
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																														
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																																														
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																																														
A	2010	HHR	Chassis	Power Steering Control Module																																																														
A	2010	HHR	Chassis	Power Steering Control Module																																																														
A	2010	HHR	Body	Body Control Module																																																														
A	2010	HHR	Body	Digital Radio Receiver																																																														
A	2010	HHR	Body	Instrument Panel Cluster																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2010	HHR	Body	Radio																																																												
A	2010	HHR	Body	Supplemental Inflatable Restraint																																																												
A	2010	HHR	Body	Theft Deterrent Module																																																												
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																												
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																												
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module										V																																																		
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																												
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module										V																																																		
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																												
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																												
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2010	HHR Panel	Body	Body Control Module																																																												
A	2010	HHR Panel	Body	Digital Radio Receiver																																																												
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																												
A	2010	HHR Panel	Body	Radio																																																												
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																																												
A	2010	HHR Panel	Body	Theft Deterrent Module																																																												
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module										V																																																		
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																												
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module										V																																																		
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																												
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																																												
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2011	HHR	Chassis	Power Steering Control Module																																																												
A	2011	HHR	Body	Body Control Module																																																												
A	2011	HHR	Body	Digital Radio Receiver																																																												
A	2011	HHR	Body	Instrument Panel Cluster																																																												
A	2011	HHR	Body	Radio																																																												
A	2011	HHR	Body	Supplemental Inflatable Restraint																																																												
A	2011	HHR	Body	Theft Deterrent Module																																																												
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module										V																																																		
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																												
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module										V																																																		
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																												
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																												
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2011	HHR Panel	Body	Body Control Module																																																												
A	2011	HHR Panel	Body	Digital Radio Receiver																																																												
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																												
A	2011	HHR Panel	Body	Radio																																																												
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																																												
A	2011	HHR Panel	Body	Theft Deterrent Module																																																												
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																												
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																												
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																													
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																													
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																													
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																													
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																													
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																													
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																													
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																													
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																													
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																													
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																													
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																													
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																													
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																													
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																													
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																													
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																													
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																													
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																													
A	2013	Trax	Chassis	Electronic Brake Control Module																																																													
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																													
A	2013	Trax	Chassis	Power Steering Control Module																																																													
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2013	Trax	Body	Body Control Module																																																												
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2013	Trax	Body	Passenger Presence Module																																																													
A	2013	Trax	Body	Instrument Cluster																																																													
A	2013	Trax	Body	Radio																																																												
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																													
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																													
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																													
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																													
A	2013	Trax	Body	Front Seat Heating Control Module																																																													
A	2013	Trax	Body	Parking Assist Control Module																																																													
A	2013	Trax	Body	Frontview Camera Module																																																													
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																													
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																													
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																													
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																													
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																													
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																													
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																													
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																													
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																												
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
A	2014	Trax	Chassis	Electronic Brake Control Module																																																												
A	2014	Trax	Chassis	Power Steering Control Module																																																												
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2014	Trax	Body	Body Control Module																																																												
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2014	Trax	Body	Passenger Presence Module																																																												
A	2014	Trax	Body	Instrument Cluster																																																												
A	2014	Trax	Body	Radio																																																												
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
A	2014	Trax	Body	Front Seat Heating Control Module																																																												
A	2014	Trax	Body	Parking Assist Control Module																																																												
A	2014	Trax	Body	Frontview Camera Module																																																												
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																												
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																												
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																												
A	2015	Trax	Powertrain	Chassis Control Module																																																												
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
A	2015	Trax	Chassis	Electronic Brake Control Module																																																												
A	2015	Trax	Chassis	Power Steering Control Module																																																												
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2015	Trax	Body	Body Control Module																																																												
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2015	Trax	Body	Passenger Presence Module																																																												
A	2015	Trax	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2015	Trax	Body	Radio																																																														
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																														
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																														
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																														
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																														
A	2015	Trax	Body	Seat Memory Control Module																																																														
A	2015	Trax	Body	Front Seat Heating Control Module																																																														
A	2015	Trax	Body	Right Side Object Detection Control Module																																																														
A	2015	Trax	Body	Left Side Object Detection Control Module																																																														
A	2015	Trax	Body	Parking Assist Control Module																																																														
A	2015	Trax	Body	Frontview Camera Module																																																														
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																														
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																														
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																														
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																														
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																														
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																														
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																														
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																														
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																														
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																														
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																														
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																														
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																														
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																														
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																														
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																														
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																														
A	2016	Trax	Powertrain	Chassis Control Module																																																														
A	2016	Trax	Chassis	Electronic Brake Control Module																																																														
A	2016	Trax	Chassis	Power Steering Control Module																																																														
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																														
A	2016	Trax	Body	Body Control Module																																																														
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
A	2016	Trax	Body	Passenger Presence Module																																																														
A	2016	Trax	Body	Instrument Cluster																																																														
A	2016	Trax	Body	Trailer Interface Control Module																																																														
A	2016	Trax	Body	Radio																																																														
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																														
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																														
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																														
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																														
A	2016	Trax	Body	Seat Memory Control Module																																																														
A	2016	Trax	Body	Front Seat Heating Control Module																																																														
A	2016	Trax	Body	Right Side Object Detection Control Module																																																														
A	2016	Trax	Body	Left Side Object Detection Control Module																																																														
A	2016	Trax	Body	Parking Assist Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2016	Trax	Body	Frontview Camera Module																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																															
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																															
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																															
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																															
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																															
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																															
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																															
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																															
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																															
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																															
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																															
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																															
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																															
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																															
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																															
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																															
C	2004	ALL	Chassis	ESC																																																															
C	2004	ALL	Chassis	Rear Wheel Steering																																																															
C	2004	ALL	Chassis	Tire Pressure Monitor																																																															
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																															
C	2004	ALL	Chassis	VSES																																																															
C	2004	ALL	Body	Amplifier (Bose)																																																															
C	2004	ALL	Body	Body Control Module																																																															
C	2004	ALL	Body	CD Changer																																																															
C	2004	ALL	Body	Chime																																																															
C	2004	ALL	Body	Driver Door Module																																																															
C	2004	ALL	Body	Driver Seat Module																																																															
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																															
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																															
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																															
C	2004	ALL	Body	Instrument Panel Cluster																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2004	ALL	Body	OnStar																																																														
C	2004	ALL	Body	Passenger Door Module																																																														
C	2004	ALL	Body	Passenger Presence System																																																														
C	2004	ALL	Body	Radio Base																																																														
C	2004	ALL	Body	Radio Uplevel																																																														
C	2004	ALL	Body	Radio Navigation																																																														
C	2004	ALL	Body	Rear Aux. Climate Module																																																														
C	2004	ALL	Body	Rear HVAC																																																														
C	2004	ALL	Body	Rear Seat Audio																																																														
C	2004	ALL	Body	Rear Seat Entertainment																																																														
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
C	2004	ALL	Body	Vehicle Theft Deterrent																																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																														
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																														
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																														
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																														
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																														
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																														
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																														
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																														
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																														
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																														
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																														
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																														
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																														
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																														
C	2005	ALL	Chassis	ESC																																																														
C	2005	ALL	Chassis	Rear Wheel Steering																																																														
C	2005	ALL	Chassis	Tire Pressure Monitor																																																														
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2005	ALL	Chassis	VSES																																																														
C	2005	ALL	Body	Amplifier (Bose)																																																														
C	2005	ALL	Body	Body Control Module																																																														
C	2005	ALL	Body	CD Changer																																																														
C	2005	ALL	Body	Chime																																																														
C	2005	ALL	Body	Disc Player and Video Display																																																														
C	2005	ALL	Body	Driver Door Module																																																														
C	2005	ALL	Body	Driver Seat Module																																																														
C	2005	ALL	Body	Generator Battery Control Module																																																														
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																														
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																														
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																														
C	2005	ALL	Body	Instrument Panel Cluster																																																														
C	2005	ALL	Body	Passenger Door Module																																																														
C	2005	ALL	Body	Passenger Presence System																																																														
C	2005	ALL	Body	Base Radio																																																														
C	2005	ALL	Body	Uplevel Radio																																																														
C	2005	ALL	Body	Navigation Radio																																																														
C	2005	ALL	Body	Rear Aux. Climate Module																																																														
C	2005	ALL	Body	Rear HVAC																																																														
C	2005	ALL	Body	Rear Seat Audio																																																														
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																														
C	2005	ALL	Body	Vehicle Theft Deterrent																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																														
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																														
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																														
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																													
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																													
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																													
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																													
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																														
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																													
C	2006	ALL	Chassis	ESC																																																													
C	2006	ALL	Chassis	Tire Pressure Monitor																																																													
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																													
C	2006	ALL	Chassis	VSES																																																													
C	2006	ALL	Body	Amplifier (Bose)																																																													
C	2006	ALL	Body	Body Control Module																																																													
C	2006	ALL	Body	CD Changer																																																													
C	2006	ALL	Body	Chime																																																													
C	2006	ALL	Body	Disc Player and Video Display																																																													
C	2006	ALL	Body	Driver Door Module																																																													
C	2006	ALL	Body	Driver Seat Module																																																													
C	2006	ALL	Body	Generator Battery Control Module																																																													
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																													
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																													
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																													
C	2006	ALL	Body	Instrument Panel Cluster																																																													
C	2006	ALL	Body	Passenger Door Module																																																													
C	2006	ALL	Body	Passenger Presence System																																																													
C	2006	ALL	Body	Base Radio																																																													
C	2006	ALL	Body	Uplevel Radio																																																													
C	2006	ALL	Body	Navigation Radio																																																													
C	2006	ALL	Body	Rear Aux. Climate Module																																																													
C	2006	ALL	Body	Rear HVAC																																																													
C	2006	ALL	Body	Rear Seat Audio																																																													
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																													
C	2006	ALL	Body	Vehicle Theft Deterrent																																																													
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																													
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																													
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																															
C	2007	Avalanche	Body	Amplifier (Bose)																																																															
C	2007	Avalanche	Body	Assist Step Controller																																																															
C	2007	Avalanche	Body	Body Control Module																																																															
C	2007	Avalanche	Body	Body Control Module (aux.)																																																															
C	2007	Avalanche	Body	Digital Radio Receiver																																																															
C	2007	Avalanche	Body	Driver Door Switch																																																															
C	2007	Avalanche	Body	HVAC Control Module Auto																																																															
C	2007	Avalanche	Body	HVAC Control Module Manual																																																															
C	2007	Avalanche	Body	Instrument Panel Cluster																																																															
C	2007	Avalanche	Body	Memory Seat Module																																																															
C	2007	Avalanche	Body	Park Assist Module																																																															
C	2007	Avalanche	Body	Passenger Door Switch																																																															
C	2007	Avalanche	Body	Passenger Presence System																																																															
C	2007	Avalanche	Body	Radio																																																															
C	2007	Avalanche	Body	Rear Heated Seat Module																																																															
C	2007	Avalanche	Body	Rear HVAC/RSA																																																															
C	2007	Avalanche	Body	Rollover Sensor																																																															
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																															
C	2007	Avalanche	Body	Theft Deterrent Module																																																															
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																															
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																															
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																															
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																															
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																															
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																															
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2007	Suburban	Chassis	Electronic Suspension Control																																																															
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																															
C	2007	Suburban	Body	Amplifier (Bose)																																																															
C	2007	Suburban	Body	Assist Step Controller																																																															
C	2007	Suburban	Body	Body Control Module																																																															
C	2007	Suburban	Body	Body Control Module (aux.)																																																															
C	2007	Suburban	Body	Digital Radio Receiver																																																															
C	2007	Suburban	Body	Driver Door Switch																																																															
C	2007	Suburban	Body	HVAC Control Module Auto																																																															
C	2007	Suburban	Body	HVAC Control Module Manual																																																															
C	2007	Suburban	Body	Instrument Panel Cluster																																																															
C	2007	Suburban	Body	Lift Gate Module																									V	V																																				
C	2007	Suburban	Body	Memory Seat Module																																																															
C	2007	Suburban	Body	Park Assist Module																																																															
C	2007	Suburban	Body	Passenger Door Switch																																																															
C	2007	Suburban	Body	Passenger Presence System																																																															
C	2007	Suburban	Body	Radio																																																															
C	2007	Suburban	Body	Rear Heated Seat Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2007	Suburban	Body	Rear HVAC/RSA																																																														
C	2007	Suburban	Body	Rollover Sensor																																																														
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																																														
C	2007	Suburban	Body	Theft Deterrent Module																																																														
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																														
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																														
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																														
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																														
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																														
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																														
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																														
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																														
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																														
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																														
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																														
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																														
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																														
C	2007	Silverado	Chassis	Electronic Suspension Control																																																														
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																														
C	2007	Silverado	Body	Amplifier (Bose)																																																														
C	2007	Silverado	Body	Body Control Module																																																														
C	2007	Silverado	Body	Body Control Module (aux.)																																																														
C	2007	Silverado	Body	Digital Radio Receiver																																																														
C	2007	Silverado	Body	Driver Door Switch																																																														
C	2007	Silverado	Body	HVAC Control Module Auto																																																														
C	2007	Silverado	Body	HVAC Control Module Manual																																																														
C	2007	Silverado	Body	Instrument Panel Cluster																																																														
C	2007	Silverado	Body	Memory Seat Module																																																														
C	2007	Silverado	Body	Park Assist Module																																																														
C	2007	Silverado	Body	Passenger Door Switch																																																														
C	2007	Silverado	Body	Passenger Presence System																																																														
C	2007	Silverado	Body	Radio																																																														
C	2007	Silverado	Body	Rear Heated Seat Module																																																														
C	2007	Silverado	Body	Rear HVAC/RSA																																																														
C	2007	Silverado	Body	Rollover Sensor																																																														
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																																														
C	2007	Silverado	Body	Theft Deterrent Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																													
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																													
C	2007	Tahoe	Body	Amplifier (Bose)																																																													
C	2007	Tahoe	Body	Assist Step Controller																																																													
C	2007	Tahoe	Body	Body Control Module																																																													
C	2007	Tahoe	Body	Body Control Module (aux.)																																																													
C	2007	Tahoe	Body	Digital Radio Receiver																																																													
C	2007	Tahoe	Body	Driver Door Switch																																																													
C	2007	Tahoe	Body	HVAC Control Module Auto																																																													
C	2007	Tahoe	Body	HVAC Control Module Manual																																																													
C	2007	Tahoe	Body	Instrument Panel Cluster																																																													
C	2007	Tahoe	Body	Lift Gate Module																									V	V																																			
C	2007	Tahoe	Body	Memory Seat Module																																																													
C	2007	Tahoe	Body	Park Assist Module																																																													
C	2007	Tahoe	Body	Passenger Door Switch																																																													
C	2007	Tahoe	Body	Passenger Presence System																																																													
C	2007	Tahoe	Body	Radio																																																													
C	2007	Tahoe	Body	Rear Heated Seat Module																																																													
C	2007	Tahoe	Body	Rear HVAC/RSA																																																													
C	2007	Tahoe	Body	Rollover Sensor																																																													
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																													
C	2007	Tahoe	Body	Theft Deterrent Module																																																													
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																													
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
C	2008	Avalanche	Chassis	Electronic Brake Control Module			V																																																										
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																													
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																													
C	2008	Avalanche	Body	Amplifier (Bose)																																																													
C	2008	Avalanche	Body	Assist Step Controller																																																													
C	2008	Avalanche	Body	Body Control Module																																																													
C	2008	Avalanche	Body	Body Control Module (aux.)																																																													
C	2008	Avalanche	Body	Digital Radio Receiver																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2008	Avalanche	Body	Driver Door Switch																																																														
C	2008	Avalanche	Body	HVAC Control Module Auto																																																														
C	2008	Avalanche	Body	HVAC Control Module Manual																																																														
C	2008	Avalanche	Body	Instrument Panel Cluster																																																														
C	2008	Avalanche	Body	Memory Seat Module																																																														
C	2008	Avalanche	Body	Park Assist Module																																																														
C	2008	Avalanche	Body	Passenger Door Switch																																																														
C	2008	Avalanche	Body	Passenger Presence System																																																														
C	2008	Avalanche	Body	Radio																																																														
C	2008	Avalanche	Body	Rear Heated Seat Module																																																														
C	2008	Avalanche	Body	Rear HVAC/RSA																																																														
C	2008	Avalanche	Body	Rollover Sensor																																																														
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																														
C	2008	Avalanche	Body	Theft Deterrent Module																																																														
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																														
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																														
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																														
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																														
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																														
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES			V																																																											
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																														
C	2008	Suburban	Chassis	Electronic Suspension Control																																																														
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																														
C	2008	Suburban	Body	Amplifier (Bose)																																																														
C	2008	Suburban	Body	Assist Step Controller																																																														
C	2008	Suburban	Body	Body Control Module																																																														
C	2008	Suburban	Body	Body Control Module (aux.)																																																														
C	2008	Suburban	Body	Digital Radio Receiver																																																														
C	2008	Suburban	Body	Driver Door Switch																																																														
C	2008	Suburban	Body	HVAC Control Module Auto																																																														
C	2008	Suburban	Body	HVAC Control Module Manual																																																														
C	2008	Suburban	Body	Instrument Panel Cluster																																																														
C	2008	Suburban	Body	Lift Gate Module																									V	V																																				
C	2008	Suburban	Body	Memory Seat Module																																																														
C	2008	Suburban	Body	Park Assist Module																																																														
C	2008	Suburban	Body	Passenger Door Switch																																																														
C	2008	Suburban	Body	Passenger Presence System																																																														
C	2008	Suburban	Body	Radio																																																														
C	2008	Suburban	Body	Rear Heated Seat Module																																																														
C	2008	Suburban	Body	Rear HVAC/RSA																																																														
C	2008	Suburban	Body	Rollover Sensor																																																														
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2008	Suburban	Body	Theft Deterrent Module																																																														
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																														
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																														
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																														
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																														
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																														
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																														
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																														
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																														
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																														
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES			V																																																											
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2008	Silverado	Chassis	Electronic Suspension Control																																																															
C	2008	Silverado	Chassis	Trailer Brake Control Module																																																															
C	2008	Silverado	Body	Amplifier (Bose)																																																															
C	2008	Silverado	Body	Body Control Module																																																															
C	2008	Silverado	Body	Body Control Module (aux.)																																																															
C	2008	Silverado	Body	Digital Radio Receiver																																																															
C	2008	Silverado	Body	Driver Door Switch																																																															
C	2008	Silverado	Body	HVAC Control Module Auto																																																															
C	2008	Silverado	Body	HVAC Control Module Manual																																																															
C	2008	Silverado	Body	Instrument Panel Cluster																																																															
C	2008	Silverado	Body	Memory Seat Module																																																															
C	2008	Silverado	Body	Park Assist Module																																																															
C	2008	Silverado	Body	Passenger Door Switch																																																															
C	2008	Silverado	Body	Passenger Presence System																																																															
C	2008	Silverado	Body	Radio																																																															
C	2008	Silverado	Body	Rear Heated Seat Module																																																															
C	2008	Silverado	Body	Rear HVAC/RSA																																																															
C	2008	Silverado	Body	Rollover Sensor																																																															
C	2008	Silverado	Body	Supplemental Inflatable Restraint																																																															
C	2008	Silverado	Body	Theft Deterrent Module																																																															
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																																															
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																															
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																															
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																													
C	2008	Tahoe	Chassis	Electronic Brake Control Module			V																																																										
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																													
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																													
C	2008	Tahoe	Body	Amplifier (Bose)																																																													
C	2008	Tahoe	Body	Assist Step Controller																																																													
C	2008	Tahoe	Body	Body Control Module																																																													
C	2008	Tahoe	Body	Body Control Module (aux.)																																																													
C	2008	Tahoe	Body	Digital Radio Receiver																																																													
C	2008	Tahoe	Body	Driver Door Switch																																																													
C	2008	Tahoe	Body	HVAC Control Module Auto																																																													
C	2008	Tahoe	Body	HVAC Control Module Manual																																																													
C	2008	Tahoe	Body	Instrument Panel Cluster																																																													
C	2008	Tahoe	Body	Memory Seat Module																																																													
C	2008	Tahoe	Body	Park Assist Module																																																													
C	2008	Tahoe	Body	Passenger Presence System																																																													
C	2008	Tahoe	Body	Radio																																																													
C	2008	Tahoe	Body	Rear Heated Seat Module																																																													
C	2008	Tahoe	Body	Rear HVAC/RSA																																																													
C	2008	Tahoe	Body	Rollover Sensor																																																													
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																													
C	2008	Tahoe	Body	Theft Deterrent Module																																																													
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																													
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																													
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																													
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																													
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																													
C	2008	Tahoe Hybrid	Body	Body Control Module																																																													
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																													
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																													
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																																													
C	2008	Tahoe Hybrid	Body	HVAC Control Module																																																													
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																													
C	2008	Tahoe Hybrid	Body	Memory Seat Module																																																													
C	2008	Tahoe Hybrid	Body	Park Assist Module																																																													
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2008	Tahoe Hybrid	Body	Radio																																																												
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																																												
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																		
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																		
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																												
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																												
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																		
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																		
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Avalanche	Chassis	Electronic Brake Control Module			V																																																									
C	2009	Avalanche	Chassis	Electronic Suspension Control																																																												
C	2009	Avalanche	Chassis	Trailer Brake Control Module																																																												
C	2009	Avalanche	Body	Amplifier (Bose)																																																												
C	2009	Avalanche	Body	Assist Step Controller																																																												
C	2009	Avalanche	Body	Body Control Module															V	V	V	V	V	V	V																																							
C	2009	Avalanche	Body	Body Control Module (aux.)																																																												
C	2009	Avalanche	Body	Digital Radio Receiver																																																												
C	2009	Avalanche	Body	Driver Door Switch																																																												
C	2009	Avalanche	Body	HVAC Control Module Auto																																																												
C	2009	Avalanche	Body	HVAC Control Module Manual																																																												
C	2009	Avalanche	Body	Instrument Panel Cluster																																																												
C	2009	Avalanche	Body	Memory Seat Module																																																												
C	2009	Avalanche	Body	Park Assist Module																																																												
C	2009	Avalanche	Body	Passenger Door Switch																																																												
C	2009	Avalanche	Body	Passenger Presence System																																																												
C	2009	Avalanche	Body	Radio																																																												
C	2009	Avalanche	Body	Rear Heated Seat Module																																																												
C	2009	Avalanche	Body	Rear HVAC/RSA																																																												
C	2009	Avalanche	Body	Rollover Sensor																																																												
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																												
C	2009	Avalanche	Body	Theft Deterrent Module																																																												
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																		
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																		
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES			V																																																									

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																													
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																													
C	2009	Cheyenne	Body	Amplifier (Bose)																																																													
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																													
C	2009	Cheyenne	Body	Digital Radio Receiver																																																													
C	2009	Cheyenne	Body	Driver Door Switch																																																													
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																													
C	2009	Cheyenne	Body	Park Assist Module																																																													
C	2009	Cheyenne	Body	Passenger Door Switch																																																													
C	2009	Cheyenne	Body	Passenger Presence System																																																													
C	2009	Cheyenne	Body	Rear Heated Seat Module																																																													
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																													
C	2009	Cheyenne	Body	Rollover Sensor																																																													
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																													
C	2009	Cheyenne	Body	Theft Deterrent Module																																																													
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																			
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																			
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																			
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																			
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																			
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
C	2009	Suburban	Chassis	EBCM Under 8600 GVW			V																																																										
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2009	Suburban	Chassis	Electronic Suspension Control																																																													
C	2009	Suburban	Chassis	Trailer Brake Control Module																																																													
C	2009	Suburban	Body	Amplifier (Bose)																																																													
C	2009	Suburban	Body	Assist Step Controller																																																													
C	2009	Suburban	Body	Body Control Module															V	V	V	V	V	V	V																																							
C	2009	Suburban	Body	Body Control Module (aux.)																																																													
C	2009	Suburban	Body	Digital Radio Receiver																																																													
C	2009	Suburban	Body	Driver Door Switch																																																													
C	2009	Suburban	Body	HVAC Control Module Auto																																																													
C	2009	Suburban	Body	HVAC Control Module Manual																																																													
C	2009	Suburban	Body	Instrument Panel Cluster																																																													
C	2009	Suburban	Body	Left Side Object Detection Module						V																																																						
C	2009	Suburban	Body	Lift Gate Module																									V	V																																			
C	2009	Suburban	Body	Memory Seat Module																																																													
C	2009	Suburban	Body	Park Assist Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2009	Suburban	Body	Passenger Door Switch																																																														
C	2009	Suburban	Body	Passenger Presence System																																																														
C	2009	Suburban	Body	Radio																																																													
C	2009	Suburban	Body	Rear Heated Seat Module																																																													
C	2009	Suburban	Body	Rear HVAC/RSA																																																													
C	2009	Suburban	Body	Right Side Object Detection Module						V																																																						
C	2009	Suburban	Body	Rollover Sensor																																																												
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																																												
C	2009	Suburban	Body	Theft Deterrent Module																																																												
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module										V																																																		
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																		
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																		
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																		
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																		
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																		
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																		
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																		
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES			V																																																									
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2009	Silverado	Chassis	Electronic Suspension Control																																																												
C	2009	Silverado	Chassis	Trailer Brake Control Module																																																												
C	2009	Silverado	Body	Amplifier (Bose)																																																												
C	2009	Silverado	Body	Body Control Module															V	V	V	V	V	V	V																																						
C	2009	Silverado	Body	Body Control Module (aux.)																																																												
C	2009	Silverado	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2009	Silverado	Body	Driver Door Switch																																																															
C	2009	Silverado	Body	HVAC Control Module Auto																																																															
C	2009	Silverado	Body	HVAC Control Module Manual																																																															
C	2009	Silverado	Body	Instrument Panel Cluster																																																															
C	2009	Silverado	Body	Memory Seat Module																																																															
C	2009	Silverado	Body	Park Assist Module																																																															
C	2009	Silverado	Body	Passenger Door Switch																																																															
C	2009	Silverado	Body	Passenger Presence System																																																															
C	2009	Silverado	Body	Radio																																																															
C	2009	Silverado	Body	Rear Heated Seat Module																																																															
C	2009	Silverado	Body	Rear HVAC/RSA																																																															
C	2009	Silverado	Body	Rollover Sensor																																																															
C	2009	Silverado	Body	Supplemental Inflatable Restraint																																																															
C	2009	Silverado	Body	Theft Deterrent Module																																																															
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																															
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																															
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																															
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																															
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																															
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																														
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																														
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																															
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																															
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																															
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																															
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																															
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																															
C	2009	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																									
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																															
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																															
C	2009	Silverado Hybrid	Body	Driver Door Switch																																																															
C	2009	Silverado Hybrid	Body	HVAC Control Module																																																															
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																															
C	2009	Silverado Hybrid	Body	Memory Seat Module																																																															
C	2009	Silverado Hybrid	Body	Park Assist Module																																																															
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																																															
C	2009	Silverado Hybrid	Body	Passenger Presence System																																																															
C	2009	Silverado Hybrid	Body	Radio																																																															
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																															
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																															
C	2009	Silverado Hybrid	Body	Rollover Sensor																																																															
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																															
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																															
C	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																															
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																					
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																																
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																															
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																				
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																			
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																			
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																			
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
C	2009	Tahoe	Chassis	Electronic Brake Control Module			V																																																										
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																													
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																																													
C	2009	Tahoe	Body	Amplifier (Bose)																																																													
C	2009	Tahoe	Body	Assist Step Controller																																																													
C	2009	Tahoe	Body	Body Control Module															V	V	V	V	V	V	V																																							
C	2009	Tahoe	Body	Body Control Module (aux.)																																																													
C	2009	Tahoe	Body	Digital Radio Receiver																																																													
C	2009	Tahoe	Body	Driver Door Switch																																																													
C	2009	Tahoe	Body	HVAC Control Module Auto																																																													
C	2009	Tahoe	Body	HVAC Control Module Manual																																																													
C	2009	Tahoe	Body	Instrument Panel Cluster																																																													
C	2009	Tahoe	Body	Left Side Object Detection Module						V																																																						
C	2009	Tahoe	Body	Lift Gate Module																								V	V																																				
C	2009	Tahoe	Body	Memory Seat Module																																																													
C	2009	Tahoe	Body	Park Assist Module																																																													
C	2009	Tahoe	Body	Passenger Door Switch																																																													
C	2009	Tahoe	Body	Passenger Presence System																																																													
C	2009	Tahoe	Body	Radio																																																												
C	2009	Tahoe	Body	Rear Heated Seat Module																																																													
C	2009	Tahoe	Body	Rear HVAC/RSA																																																													
C	2009	Tahoe	Body	Right Side Object Detection Module						V																																																						
C	2009	Tahoe	Body	Rollover Sensor																																																													
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																													
C	2009	Tahoe	Body	Theft Deterrent Module																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																													
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																													
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																													
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																													
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																													
C	2009	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																							

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																																												
C	2009	Tahoe Hybrid	Body	HVAC Control Module																																																												
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module						V																																																						
C	2009	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																												
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																																												
C	2009	Tahoe Hybrid	Body	Radio																																																												
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module						V																																																						
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																												
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Avalanche	Chassis	Electronic Brake Control Module			V																																																									
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																												
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Avalanche	Body	Amplifier (Bose)																																																												
C	2010	Avalanche	Body	Assist Step Controller																																																												
C	2010	Avalanche	Body	Body Control Module															V	V	V	V	V	V	V																																							
C	2010	Avalanche	Body	Body Control Module (aux.)																																																												
C	2010	Avalanche	Body	Digital Radio Receiver																																																												
C	2010	Avalanche	Body	Driver Door Switch																																																												
C	2010	Avalanche	Body	HVAC Control Module Auto																																																												
C	2010	Avalanche	Body	HVAC Control Module Manual																																																												
C	2010	Avalanche	Body	Instrument Panel Cluster																																																												
C	2010	Avalanche	Body	Memory Seat Module																																																												
C	2010	Avalanche	Body	Park Assist Module																																																												
C	2010	Avalanche	Body	Passenger Door Switch																																																												
C	2010	Avalanche	Body	Passenger Presence System																																																												
C	2010	Avalanche	Body	Radio																																																												
C	2010	Avalanche	Body	Rear Heated Seat Module																																																												
C	2010	Avalanche	Body	Rear HVAC/RSA																																																												
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
C	2010	Avalanche	Body	Theft Deterrent Module																																																												
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES			V																																																								
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																											
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Cheyenne	Body	Amplifier (Bose)																																																											
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																											
C	2010	Cheyenne	Body	Digital Radio Receiver																																																											
C	2010	Cheyenne	Body	Driver Door Switch																																																											
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																											
C	2010	Cheyenne	Body	Park Assist Module																																																											
C	2010	Cheyenne	Body	Passenger Door Switch																																																											
C	2010	Cheyenne	Body	Passenger Presence System																																																											
C	2010	Cheyenne	Body	Rear Heated Seat Module																																																											
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																											
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
C	2010	Cheyenne	Body	Theft Deterrent Module																																																											
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2010	Suburban	Chassis	EBCM Under 8600 GVW			V																																																								
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2010	Suburban	Chassis	Electronic Suspension Control																																																											
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Suburban	Body	Amplifier (Bose)																																																											
C	2010	Suburban	Body	Assist Step Controller																																																											
C	2010	Suburban	Body	Body Control Module															V	V	V	V	V	V	V																																					
C	2010	Suburban	Body	Body Control Module (aux.)																																																											
C	2010	Suburban	Body	Digital Radio Receiver																																																											
C	2010	Suburban	Body	Driver Door Switch																																																											
C	2010	Suburban	Body	HVAC Control Module Auto																																																											
C	2010	Suburban	Body	HVAC Control Module Manual																																																											
C	2010	Suburban	Body	Instrument Panel Cluster																																																											
C	2010	Suburban	Body	Left Side Object Detection Module						V																																																					
C	2010	Suburban	Body	Lift Gate Module																									V	V			V	V																													
C	2010	Suburban	Body	Memory Seat Module																																																											
C	2010	Suburban	Body	Park Assist Module																																																											
C	2010	Suburban	Body	Passenger Door Switch																																																											
C	2010	Suburban	Body	Passenger Presence System																																																											
C	2010	Suburban	Body	Radio																																																											
C	2010	Suburban	Body	Rear Heated Seat Module																																																											
C	2010	Suburban	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2010	Suburban	Body	Right Side Object Detection Module						V																																																							
C	2010	Suburban	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
C	2010	Suburban	Body	Theft Deterrent Module																																																												
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																													
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																													
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																													
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																													
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																													
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																													
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES			V																																																											
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																														
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																													
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													
C	2010	Silverado	Chassis	Electronic Suspension Control																																																													
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																													
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																													
C	2010	Silverado	Body	Amplifier (Bose)																																																													
C	2010	Silverado	Body	Body Control Module															V	V	V	V	V	V	V																																							
C	2010	Silverado	Body	Body Control Module (aux.)																																																													
C	2010	Silverado	Body	Digital Radio Receiver																																																													
C	2010	Silverado	Body	Driver Door Switch																																																												
C	2010	Silverado	Body	HVAC Control Module Auto																																																												
C	2010	Silverado	Body	HVAC Control Module Manual																																																												
C	2010	Silverado	Body	Instrument Panel Cluster																																																												
C	2010	Silverado	Body	Memory Seat Module																																																												
C	2010	Silverado	Body	Park Assist Module																																																												
C	2010	Silverado	Body	Passenger Door Switch																																																												
C	2010	Silverado	Body	Passenger Presence System																																																												
C	2010	Silverado	Body	Radio																																																											
C	2010	Silverado	Body	Rear Heated Seat Module																																																												
C	2010	Silverado	Body	Rear HVAC/RSA																																																												
C	2010	Silverado	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
C	2010	Silverado	Body	Theft Deterrent Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																														
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																													
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																													
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																													
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																													
C	2010	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																								
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																													
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																													
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																													
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																													
C	2010	Silverado Hybrid	Body	HVAC Control Module																																																													
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																													
C	2010	Silverado Hybrid	Body	Park Assist Module																																																													
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																													
C	2010	Silverado Hybrid	Body	Passenger Presence System																																																													
C	2010	Silverado Hybrid	Body	Radio																																																													
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																													
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																													
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																													
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																													
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2010	Tahoe	Chassis	Electronic Brake Control Module			V																																																										
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																													
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Tahoe	Body	Amplifier (Bose)																																																													
C	2010	Tahoe	Body	Assist Step Controller																																																													
C	2010	Tahoe	Body	Body Control Module															V	V	V	V	V	V	V																																								
C	2010	Tahoe	Body	Body Control Module (aux.)																																																													
C	2010	Tahoe	Body	Digital Radio Receiver																																																													
C	2010	Tahoe	Body	Driver Door Switch																																																													
C	2010	Tahoe	Body	HVAC Control Module Auto																																																													
C	2010	Tahoe	Body	HVAC Control Module Manual																																																													
C	2010	Tahoe	Body	Instrument Panel Cluster																																																													
C	2010	Tahoe	Body	Left Side Object Detection Module						V																																																						
C	2010	Tahoe	Body	Lift Gate Module																									V	V			V	V																														
C	2010	Tahoe	Body	Memory Seat Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2010	Tahoe	Body	Park Assist Module																																																															
C	2010	Tahoe	Body	Passenger Door Switch																																																															
C	2010	Tahoe	Body	Passenger Presence System																																																															
C	2010	Tahoe	Body	Radio																																																															
C	2010	Tahoe	Body	Rear Heated Seat Module																																																															
C	2010	Tahoe	Body	Rear HVAC/RSA																																																															
C	2010	Tahoe	Body	Right Side Object Detection Module						V																																																									
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																															V	V	V	V																													
C	2010	Tahoe	Body	Theft Deterrent Module																																																															
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																																
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																																
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																																
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																																
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																																
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																															
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																																
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																																
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																																
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																																
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																																
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																																
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																																
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																																
C	2010	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																										
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																																
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																																
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																																																
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																																																
C	2010	Tahoe Hybrid	Body	HVAC Control Module																																																																
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																																
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module						V																																																									
C	2010	Tahoe Hybrid	Body	Lift Gate Module																									V	V			V	V																																	
C	2010	Tahoe Hybrid	Body	Park Assist Module																																																																
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																																
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																																																
C	2010	Tahoe Hybrid	Body	Radio																																																																
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																																
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																																
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module						V																																																									
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																																
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																													
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																																
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																																
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																																
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																																
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
C	2011	Avalanche	Chassis	Electronic Brake Control Module			V																																																												
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																																
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																																

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2011	Avalanche	Body	Amplifier (Bose)																																																												
C	2011	Avalanche	Body	Assist Step Controller																																																												
C	2011	Avalanche	Body	Body Control Module															V	V	V	V	V	V	V																																							
C	2011	Avalanche	Body	Body Control Module (aux.)																																																												
C	2011	Avalanche	Body	Digital Radio Receiver																																																												
C	2011	Avalanche	Body	Driver Door Switch																																																												
C	2011	Avalanche	Body	HVAC Control Module Auto																																																												
C	2011	Avalanche	Body	HVAC Control Module Manual																																																												
C	2011	Avalanche	Body	Instrument Panel Cluster																																																												
C	2011	Avalanche	Body	Memory Seat Module																																																												
C	2011	Avalanche	Body	Park Assist Module																																																												
C	2011	Avalanche	Body	Passenger Door Switch																																																												
C	2011	Avalanche	Body	Passenger Presence System																																																												
C	2011	Avalanche	Body	Radio																																																												
C	2011	Avalanche	Body	Rear Heated Seat Module																																																												
C	2011	Avalanche	Body	Rear HVAC/RSA																																																												
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
C	2011	Avalanche	Body	Theft Deterrent Module																																																												
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																												
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																												
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																												
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																												
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
C	2011	Captiva	Chassis	Electronic Brake Control Module																																																												
C	2011	Captiva	Chassis	Parking Brake Control Module																																																												
C	2011	Captiva	Body	Body Control Module																																				V								V	V													
C	2011	Captiva	Body	Auxiliary Body Control Module																																																												
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2011	Captiva	Body	Instrument Cluster																																																												
C	2011	Captiva	Body	Headlamp Control Module																																																												
C	2011	Captiva	Body	HVAC Control Module																																																												
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																												
C	2011	Captiva	Body	Parking Assist Control Module																																																												
C	2011	Captiva	Body	Theft Deterrent Module																																																												
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES			V																																																									
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																												
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																												
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
C	2011	Cheyenne	Body	Amplifier (Bose)																																																												
C	2011	Cheyenne	Body	Body Control Module															V	V	V	V	V	V	V																																							
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																												
C	2011	Cheyenne	Body	Digital Radio Receiver																																																												
C	2011	Cheyenne	Body	Driver Door Switch																																																												
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																												
C	2011	Cheyenne	Body	Park Assist Module																																																												
C	2011	Cheyenne	Body	Passenger Door Switch																																																												
C	2011	Cheyenne	Body	Passenger Presence System																																																												
C	2011	Cheyenne	Body	Rear Heated Seat Module																																																												
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																												
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
C	2011	Cheyenne	Body	Theft Deterrent Module																																																												
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2011	Suburban	Chassis	EBCM Under 8600 GVW			V																																																									
C	2011	Suburban	Chassis	Electronic Suspension Control																																																												
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
C	2011	Suburban	Body	Amplifier (Bose)																																																												
C	2011	Suburban	Body	Assist Step Controller																																																												
C	2011	Suburban	Body	Body Control Module															V	V	V	V	V	V	V																																							
C	2011	Suburban	Body	Body Control Module (aux.)																																																												
C	2011	Suburban	Body	Digital Radio Receiver																																																												
C	2011	Suburban	Body	Driver Door Switch																																																												
C	2011	Suburban	Body	HVAC Control Module Auto																																																												
C	2011	Suburban	Body	HVAC Control Module Manual																																																												
C	2011	Suburban	Body	Instrument Panel Cluster																																																												
C	2011	Suburban	Body	Left Side Object Detection Module						V																																																						
C	2011	Suburban	Body	Lift Gate Module																									V	V			V	V																														
C	2011	Suburban	Body	Memory Seat Module																																																												
C	2011	Suburban	Body	Park Assist Module																																																												
C	2011	Suburban	Body	Passenger Door Switch																																																												
C	2011	Suburban	Body	Passenger Presence System																																																												
C	2011	Suburban	Body	Radio																																																												
C	2011	Suburban	Body	Rear Heated Seat Module																																																												
C	2011	Suburban	Body	Rear HVAC/RSA																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2011	Suburban	Body	Right Side Object Detection Module						V																																																							
C	2011	Suburban	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
C	2011	Suburban	Body	Theft Deterrent Module																																																											
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic										V																																																	
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																											
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																											
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module										V																																																
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																											
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																											
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES			V																																																								
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2011	Silverado	Chassis	Electronic Suspension Control																																																											
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2011	Silverado	Body	Amplifier (Bose)																																																											
C	2011	Silverado	Body	Body Control Module															V	V	V	V	V	V	V																																						
C	2011	Silverado	Body	Body Control Module (aux.)																																																											
C	2011	Silverado	Body	Digital Radio Receiver																																																											
C	2011	Silverado	Body	Driver Door Switch																																																											
C	2011	Silverado	Body	HVAC Control Module Auto																																																											
C	2011	Silverado	Body	HVAC Control Module Manual																																																											
C	2011	Silverado	Body	Instrument Panel Cluster																																																											
C	2011	Silverado	Body	Memory Seat Module																																																											
C	2011	Silverado	Body	Park Assist Module																																																											
C	2011	Silverado	Body	Passenger Door Switch																																																											
C	2011	Silverado	Body	Passenger Presence System																																																											
C	2011	Silverado	Body	Radio																																																											
C	2011	Silverado	Body	Rear Heated Seat Module																																																											
C	2011	Silverado	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																V	V	V	V																							
C	2011	Silverado	Body	Theft Deterrent Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																					
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2011	Silverado Hybrid	Body	HVAC Control Module																																																										
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Silverado Hybrid	Body	Park Assist Module																																																										
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2011	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2011	Silverado Hybrid	Body	Radio																																																										
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																V	V	V	V																							
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Tahoe	Chassis	Electronic Brake Control Module			V																																																							
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe	Body	Amplifier (Bose)																																																										
C	2011	Tahoe	Body	Assist Step Controller																																																										
C	2011	Tahoe	Body	Body Control Module															V	V	V	V	V	V	V																																					
C	2011	Tahoe	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe	Body	Digital Radio Receiver																																																										
C	2011	Tahoe	Body	Driver Door Switch																																																										
C	2011	Tahoe	Body	HVAC Control Module Auto																																																										
C	2011	Tahoe	Body	HVAC Control Module Manual																																																										
C	2011	Tahoe	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe	Body	Left Side Object Detection Module						V																																																				
C	2011	Tahoe	Body	Lift Gate Module																									V	V			V	V																												
C	2011	Tahoe	Body	Memory Seat Module																																																										
C	2011	Tahoe	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2011	Tahoe	Body	Passenger Door Switch																																																											
C	2011	Tahoe	Body	Passenger Presence System																																																											
C	2011	Tahoe	Body	Radio																																																										
C	2011	Tahoe	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe	Body	Right Side Object Detection Module						V																																																				
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
C	2011	Tahoe	Body	Theft Deterrent Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																				
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2011	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module						V																																																			
C	2011	Tahoe Hybrid	Body	Lift Gate Module																									V	V			V	V																												
C	2011	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2011	Tahoe Hybrid	Body	Radio																																																										
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module						V																																																			
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Avalanche	Chassis	Electronic Brake Control Module			V																																																							
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2012	Avalanche	Body	Amplifier (Bose)																																																											
C	2012	Avalanche	Body	Assist Step Controller																																																											
C	2012	Avalanche	Body	Body Control Module															V	V	V	V	V	V	V																																						
C	2012	Avalanche	Body	Body Control Module (aux.)																																																											
C	2012	Avalanche	Body	Digital Radio Receiver																																																											
C	2012	Avalanche	Body	Driver Door Switch																																																											
C	2012	Avalanche	Body	HVAC Control Module Auto																																																											
C	2012	Avalanche	Body	HVAC Control Module Manual																																																											
C	2012	Avalanche	Body	Instrument Panel Cluster																																																											
C	2012	Avalanche	Body	Memory Seat Module																																																											
C	2012	Avalanche	Body	Navigation Radio																																																											
C	2012	Avalanche	Body	Park Assist Module																																																											
C	2012	Avalanche	Body	Passenger Door Switch																																																											
C	2012	Avalanche	Body	Passenger Presence System																																																											
C	2012	Avalanche	Body	Radio																																																											
C	2012	Avalanche	Body	Rear Heated Seat Module																																																											
C	2012	Avalanche	Body	Rear HVAC/RSA																																																											
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
C	2012	Avalanche	Body	Theft Deterrent Module																																																											
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																											
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																											
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																											
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																											
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																											
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																											
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																											
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																											
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																											
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																											
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																											
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																											
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																											
C	2012	Captiva	Chassis	Parking Brake Control Module																																																											
C	2012	Captiva	Body	Body Control Module																																				V									V	V											
C	2012	Captiva	Body	Auxiliary Body Control Module																																																											
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2012	Captiva	Body	Instrument Cluster																																																											
C	2012	Captiva	Body	Headlamp Control Module																																																											
C	2012	Captiva	Body	HVAC Control Module																																																											
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																											
C	2012	Captiva	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2012	Captiva	Body	Theft Deterrent Module																																																														
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																														
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																														
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES			V																																																											
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																														
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																														
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																														
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																														
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																														
C	2012	Cheyenne	Body	Amplifier (Bose)																																																														
C	2012	Cheyenne	Body	Body Control Module															V	V	V	V	V	V	V																																								
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																														
C	2012	Cheyenne	Body	Digital Radio Receiver																																																														
C	2012	Cheyenne	Body	Driver Door Switch																																																														
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																														
C	2012	Cheyenne	Body	Park Assist Module																																																														
C	2012	Cheyenne	Body	Passenger Door Switch																																																														
C	2012	Cheyenne	Body	Passenger Presence System																																																														
C	2012	Cheyenne	Body	Rear Heated Seat Module																																																														
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																														
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																															V	V	V	V																												
C	2012	Cheyenne	Body	Theft Deterrent Module																																																														
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																														
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
C	2012	Suburban	Chassis	EBCM Under 8600 GVW			V																																																											
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																														
C	2012	Suburban	Chassis	Electronic Suspension Control																																																														
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																														
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																														
C	2012	Suburban	Body	Amplifier (Bose)																																																														
C	2012	Suburban	Body	Assist Step Controller																																																														
C	2012	Suburban	Body	Body Control Module															V	V	V	V	V	V	V																																								
C	2012	Suburban	Body	Body Control Module (aux.)																																																														
C	2012	Suburban	Body	Digital Radio Receiver																																																														
C	2012	Suburban	Body	Driver Door Switch																																																														
C	2012	Suburban	Body	HVAC Control Module Auto																																																														
C	2012	Suburban	Body	HVAC Control Module Manual																																																														
C	2012	Suburban	Body	Instrument Panel Cluster																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2012	Suburban	Body	Left Side Object Detection Module						V																																																					
C	2012	Suburban	Body	Lift Gate Module																								V	V			V	V																													
C	2012	Suburban	Body	Memory Seat Module																																																										
C	2012	Suburban	Body	Navigation Radio																																																										
C	2012	Suburban	Body	Park Assist Module																																																										
C	2012	Suburban	Body	Passenger Door Switch																																																										
C	2012	Suburban	Body	Passenger Presence System																																																										
C	2012	Suburban	Body	Radio																																																										
C	2012	Suburban	Body	Rear Heated Seat Module																																																										
C	2012	Suburban	Body	Rear HVAC/RSA																																																										
C	2012	Suburban	Body	Right Side Object Detection Module						V																																																				
C	2012	Suburban	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
C	2012	Suburban	Body	Theft Deterrent Module																																																										
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic										V																																																
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																										
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module										V																																																
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES			V																																																							
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2012	Silverado	Chassis	Electronic Suspension Control																																																										
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2012	Silverado	Body	Amplifier (Bose)																																																										
C	2012	Silverado	Body	Body Control Module															V	V	V	V	V	V	V																																					
C	2012	Silverado	Body	Body Control Module (aux.)																																																										
C	2012	Silverado	Body	Digital Radio Receiver																																																										
C	2012	Silverado	Body	Driver Door Switch																																																										
C	2012	Silverado	Body	HVAC Control Module Auto																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2012	Silverado	Body	HVAC Control Module Manual																																																											
C	2012	Silverado	Body	Instrument Panel Cluster																																																											
C	2012	Silverado	Body	Memory Seat Module																																																											
C	2012	Silverado	Body	Navigation Radio																																																											
C	2012	Silverado	Body	Park Assist Module																																																											
C	2012	Silverado	Body	Passenger Door Switch																																																											
C	2012	Silverado	Body	Passenger Presence System																																																											
C	2012	Silverado	Body	Radio																																																											
C	2012	Silverado	Body	Rear Heated Seat Module																																																											
C	2012	Silverado	Body	Rear HVAC/RSA																																																											
C	2012	Silverado	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
C	2012	Silverado	Body	Theft Deterrent Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																												
C	2012	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																						
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																												
C	2012	Silverado Hybrid	Body	Driver Door Switch																																																												
C	2012	Silverado Hybrid	Body	Heated Seat Module																																																												
C	2012	Silverado Hybrid	Body	HVAC Control Module																																																												
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
C	2012	Silverado Hybrid	Body	Navigation Radio																																																												
C	2012	Silverado Hybrid	Body	Park Assist Module																																																												
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																																												
C	2012	Silverado Hybrid	Body	Passenger Presence System																																																												
C	2012	Silverado Hybrid	Body	Radio																																																												
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																												
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2012	Tahoe	Chassis	Electronic Brake Control Module			V																																																									
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
C	2012	Tahoe	Body	Amplifier (Bose)																																																												
C	2012	Tahoe	Body	Assist Step Controller																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2012	Tahoe	Body	Body Control Module															V	V	V	V	V	V	V																																							
C	2012	Tahoe	Body	Body Control Module (aux.)																																																													
C	2012	Tahoe	Body	Digital Radio Receiver																																																													
C	2012	Tahoe	Body	Driver Door Switch																																																													
C	2012	Tahoe	Body	HVAC Control Module Auto																																																													
C	2012	Tahoe	Body	HVAC Control Module Manual																																																													
C	2012	Tahoe	Body	Instrument Panel Cluster																																																													
C	2012	Tahoe	Body	Left Side Object Detection Module						V																																																						
C	2012	Tahoe	Body	Lift Gate Module																									V	V			V	V																															
C	2012	Tahoe	Body	Memory Seat Module																																																													
C	2012	Tahoe	Body	Navigation Radio																																																													
C	2012	Tahoe	Body	Park Assist Module																																																													
C	2012	Tahoe	Body	Passenger Door Switch																																																													
C	2012	Tahoe	Body	Passenger Presence System																																																													
C	2012	Tahoe	Body	Radio																																																													
C	2012	Tahoe	Body	Rear Heated Seat Module																																																													
C	2012	Tahoe	Body	Rear HVAC/RSA																																																													
C	2012	Tahoe	Body	Right Side Object Detection Module						V																																																							
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
C	2012	Tahoe	Body	Theft Deterrent Module																																																													
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																													
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																													
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																													
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																													
C	2012	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																								
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																													
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																													
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																																													
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																																													
C	2012	Tahoe Hybrid	Body	HVAC Control Module																																																													
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																													
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module						V																																																						
C	2012	Tahoe Hybrid	Body	Lift Gate Module																									V	V			V	V																															
C	2012	Tahoe Hybrid	Body	Navigation Radio																																																													
C	2012	Tahoe Hybrid	Body	Park Assist Module																																																													
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																													
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																																													
C	2012	Tahoe Hybrid	Body	Radio																																																													
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																													
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																													
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module						V																																																						

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2013	Avalanche	Chassis	Electronic Brake Control Module			V																																																									
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																												
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
C	2013	Avalanche	Body	Amplifier (Bose)																																																												
C	2013	Avalanche	Body	Assist Step Controller																																																												
C	2013	Avalanche	Body	Body Control Module															V	V	V	V	V	V	V																																							
C	2013	Avalanche	Body	Body Control Module (aux.)																																																												
C	2013	Avalanche	Body	Digital Radio Receiver																																																												
C	2013	Avalanche	Body	Driver Door Switch																																																												
C	2013	Avalanche	Body	HVAC Control Module Auto																																																												
C	2013	Avalanche	Body	HVAC Control Module Manual																																																												
C	2013	Avalanche	Body	Instrument Panel Cluster																																																												
C	2013	Avalanche	Body	Memory Seat Module																																																												
C	2013	Avalanche	Body	Navigation Radio																																																												
C	2013	Avalanche	Body	Park Assist Module																																																												
C	2013	Avalanche	Body	Passenger Door Switch																																																												
C	2013	Avalanche	Body	Passenger Presence System																																																												
C	2013	Avalanche	Body	Radio																																																												
C	2013	Avalanche	Body	Rear Heated Seat Module																																																												
C	2013	Avalanche	Body	Rear HVAC/RSA																																																												
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
C	2013	Avalanche	Body	Theft Deterrent Module																																																												
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																												
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																												
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																												
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																												
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																												
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																												
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
C	2013	Captiva	Chassis	Electronic Brake Control Module																																																												
C	2013	Captiva	Chassis	Parking Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																				V								V	V										
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																				V								V	V										
C	2013	Captiva	Body	Auxiliary Body Control Module																																																								
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
C	2013	Captiva	Body	Instrument Cluster																																																							
C	2013	Captiva	Body	Headlamp Control Module																																																							
C	2013	Captiva	Body	HVAC Control Module																																																							
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																							
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																							
C	2013	Captiva	Body	Theft Deterrent Module																																																							
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																							
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																							
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																							
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																							
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																							
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																							
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES			V																																																				
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																							
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																							
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																							
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																							
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																							
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																							
C	2013	Cheyenne	Body	Amplifier (Bose)																																																							
C	2013	Cheyenne	Body	Body Control Module															V	V	V	V	V	V	V																																			
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																							
C	2013	Cheyenne	Body	Digital Radio Receiver																																																							
C	2013	Cheyenne	Body	Driver Door Switch																																																							
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																							
C	2013	Cheyenne	Body	Park Assist Module																																																							
C	2013	Cheyenne	Body	Passenger Door Switch																																																							
C	2013	Cheyenne	Body	Passenger Presence System																																																							
C	2013	Cheyenne	Body	Rear Heated Seat Module																																																							
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																							
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																															V	V	V	V																						
C	2013	Cheyenne	Body	Theft Deterrent Module																																																							
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																							
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																							
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																							
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																							
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																							
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
C	2013	Suburban	Chassis	EBCM Under 8600 GVW			V																																																				
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																							
C	2013	Suburban	Chassis	Electronic Suspension Control																																																							
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																							

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																														
C	2013	Suburban	Body	Amplifier (Bose)																																																														
C	2013	Suburban	Body	Assist Step Controller																																																														
C	2013	Suburban	Body	Body Control Module															V	V	V	V	V	V	V																																									
C	2013	Suburban	Body	Body Control Module (aux.)																																																														
C	2013	Suburban	Body	Digital Radio Receiver																																																														
C	2013	Suburban	Body	Driver Door Switch																																																														
C	2013	Suburban	Body	HVAC Control Module Auto																																																														
C	2013	Suburban	Body	HVAC Control Module Manual																																																														
C	2013	Suburban	Body	Instrument Panel Cluster																																																														
C	2013	Suburban	Body	Left Side Object Detection Module						V																																																							
C	2013	Suburban	Body	Lift Gate Module																									V	V			V	V																																	
C	2013	Suburban	Body	Memory Seat Module																																																														
C	2013	Suburban	Body	Navigation Radio																																																														
C	2013	Suburban	Body	Park Assist Module																																																														
C	2013	Suburban	Body	Passenger Door Switch																																																														
C	2013	Suburban	Body	Passenger Presence System																																																														
C	2013	Suburban	Body	Radio																																																														
C	2013	Suburban	Body	Rear Heated Seat Module																																																														
C	2013	Suburban	Body	Rear HVAC/RSA																																																														
C	2013	Suburban	Body	Right Side Object Detection Module						V																																																								
C	2013	Suburban	Body	Supplemental Inflatable Restraint																															V	V	V	V																												
C	2013	Suburban	Body	Theft Deterrent Module																																																														
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																															
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																															
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																															
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																															
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																															
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic										V																																																				
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																															
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																				
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																															
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																															
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module										V																																																				
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																															
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																															
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES			V																																																											
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2013	Silverado	Chassis	Electronic Suspension Control																																																													
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2013	Silverado	Body	Amplifier (Bose)																																																												
C	2013	Silverado	Body	Body Control Module															V	V	V	V	V	V	V																																						
C	2013	Silverado	Body	Body Control Module (aux.)																																																												
C	2013	Silverado	Body	Digital Radio Receiver																																																												
C	2013	Silverado	Body	Driver Door Switch																																																												
C	2013	Silverado	Body	HVAC Control Module Auto																																																												
C	2013	Silverado	Body	HVAC Control Module Manual																																																												
C	2013	Silverado	Body	Instrument Panel Cluster																																																												
C	2013	Silverado	Body	Memory Seat Module																																																												
C	2013	Silverado	Body	Navigation Radio																																																												
C	2013	Silverado	Body	Park Assist Module																																																												
C	2013	Silverado	Body	Passenger Door Switch																																																												
C	2013	Silverado	Body	Passenger Presence System																																																												
C	2013	Silverado	Body	Radio																																																												
C	2013	Silverado	Body	Rear Heated Seat Module																																																												
C	2013	Silverado	Body	Rear HVAC/RSA																																																												
C	2013	Silverado	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
C	2013	Silverado	Body	Theft Deterrent Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																												
C	2013	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																						
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																												
C	2013	Silverado Hybrid	Body	Driver Door Switch																																																												
C	2013	Silverado Hybrid	Body	Heated Seat Module																																																												
C	2013	Silverado Hybrid	Body	HVAC Control Module																																																												
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
C	2013	Silverado Hybrid	Body	Navigation Radio																																																												
C	2013	Silverado Hybrid	Body	Park Assist Module																																																												
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																																												
C	2013	Silverado Hybrid	Body	Passenger Presence System																																																												
C	2013	Silverado Hybrid	Body	Radio																																																												
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2013	Tahoe	Chassis	Electronic Brake Control Module			V																																																									
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
C	2013	Tahoe	Body	Amplifier (Bose)																																																												
C	2013	Tahoe	Body	Assist Step Controller																																																												
C	2013	Tahoe	Body	Body Control Module															V	V	V	V	V	V	V																																						
C	2013	Tahoe	Body	Body Control Module (aux.)																																																												
C	2013	Tahoe	Body	Digital Radio Receiver																																																												
C	2013	Tahoe	Body	Driver Door Switch																																																												
C	2013	Tahoe	Body	HVAC Control Module Auto																																																												
C	2013	Tahoe	Body	HVAC Control Module Manual																																																												
C	2013	Tahoe	Body	Instrument Panel Cluster																																																												
C	2013	Tahoe	Body	Left Side Object Detection Module						V																																																					
C	2013	Tahoe	Body	Lift Gate Module																									V	V			V	V																														
C	2013	Tahoe	Body	Memory Seat Module																																																											
C	2013	Tahoe	Body	Navigation Radio																																																											
C	2013	Tahoe	Body	Park Assist Module																																																											
C	2013	Tahoe	Body	Passenger Door Switch																																																											
C	2013	Tahoe	Body	Passenger Presence System																																																											
C	2013	Tahoe	Body	Radio																																																										
C	2013	Tahoe	Body	Rear Heated Seat Module																																																											
C	2013	Tahoe	Body	Rear HVAC/RSA																																																											
C	2013	Tahoe	Body	Right Side Object Detection Module						V																																																					
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
C	2013	Tahoe	Body	Theft Deterrent Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2013	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																						
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																																												
C	2013	Tahoe Hybrid	Body	HVAC Control Module																																																												
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module						V																																																					
C	2013	Tahoe Hybrid	Body	Lift Gate Module																								V	V			V	V																														
C	2013	Tahoe Hybrid	Body	Navigation Radio																																																											
C	2013	Tahoe Hybrid	Body	Park Assist Module																																																											
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																											
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																																											
C	2013	Tahoe Hybrid	Body	Radio																																																											
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module						V																																																					
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																												
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																												
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																												
C	2014	Captiva (3GN)	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V														
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Captiva (3GN)	Body	Passenger Presence Module																																																		V										
C	2014	Captiva (3GN)	Body	Instrument Cluster																																																												
C	2014	Captiva (3GN)	Body	Radio																																																												
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																												
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Captiva (3GN)	Body	HVAC Control Module																																																		V	V									
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																												
C	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																												
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																												
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																												
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																												
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																												
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																												
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																												
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																												
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																												
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																				V								V	V											
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																				V								V	V											
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Captiva (Other)	Body	Instrument Cluster																																																												
C	2014	Captiva (Other)	Body	Headlamp Control Module																																																												
C	2014	Captiva (Other)	Body	HVAC Control Module																																																												
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																												
C	2014	Captiva (Other)	Body	Theft Deterrent Module																																																												
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																												
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																												
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																												
C	2014	Cheyenne	Chassis	Power Steering Control Module																																																												
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2014	Cheyenne	Body	Body Control Module																																																												
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Cheyenne	Body	Passenger Presence Module																																																												
C	2014	Cheyenne	Body	Instrument Cluster																																																												
C	2014	Cheyenne	Body	Radio Control																																																												
C	2014	Cheyenne	Body	HVAC Control																																																												
C	2014	Cheyenne	Body	Radio																																																												
C	2014	Cheyenne	Body	Amplifier																																																												
C	2014	Cheyenne	Body	Media Disc Player																																																												
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																												
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																												
C	2014	Cheyenne	Body	HVAC Control Module																																																												
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																												
C	2014	Cheyenne	Body	Parking Assist Control Module																																																												
C	2014	Cheyenne	Body	Frontview Camera Module																																																												
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																													
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																													
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																													
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																													
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																													
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
C	2014	Silverado	Chassis	Electronic Brake Control Module																																																													
C	2014	Silverado	Chassis	Parking Brake Control Module																																																													
C	2014	Silverado	Chassis	Power Steering Control Module																																																													
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2014	Silverado	Body	Body Control Module																																																													
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2014	Silverado	Body	Passenger Presence Module																																																													
C	2014	Silverado	Body	Instrument Cluster																																																													
C	2014	Silverado	Body	Radio Control																																																												
C	2014	Silverado	Body	HVAC Control																																																												
C	2014	Silverado	Body	Radio																																																												
C	2014	Silverado	Body	Amplifier																																																												
C	2014	Silverado	Body	Media Disc Player																																																												
C	2014	Silverado	Body	Human Machine Interface Control Module																																																												
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																												
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																												
C	2014	Silverado	Body	Parking Assist Control Module																																																												
C	2014	Silverado	Body	Frontview Camera Module																																																												
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																												
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																												
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																												
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																												
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																												
C	2014	Silverado HD	Chassis	Suspension Control Module																																																												
C	2014	Silverado HD	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V												
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Silverado HD	Body	Passenger Presence Module																																																												
C	2014	Silverado HD	Body	Instrument Cluster																																																												
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																												
C	2014	Silverado HD	Body	Base Radio																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2014	Silverado HD	Body	Navigation Radio																																																												
C	2014	Silverado HD	Body	Uplevel Radio																																																												
C	2014	Silverado HD	Body	Amplifier																																																												
C	2014	Silverado HD	Body	Rear Audio Control Module																																																												
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																												
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																												
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																		V									
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																		V									
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																		V									
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																		V									
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																											
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																											
C	2014	Silverado HD	Body	Seat Memory Control Module																																																									V	V
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																											
C	2014	Silverado HD	Body	Parking Assist Control Module																																																											
C	2014	Silverado HD	Body	Theft Deterrent Module																																																											
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																											
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																											
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																											
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																											
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																											
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																											
C	2014	Suburban	Chassis	Parking Brake Control Module																																																											
C	2014	Suburban	Chassis	Suspension Control Module																																																											
C	2014	Suburban	Body	Body Control Module																																					V	V	V	V	V	V	V	V	V	V												
C	2014	Suburban	Body	Auxiliary Body Control Module																																																											
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Suburban	Body	Passenger Presence Module																																																	V									
C	2014	Suburban	Body	Instrument Cluster																																																											
C	2014	Suburban	Body	Base Radio																																																											
C	2014	Suburban	Body	Navigation Radio																																																											
C	2014	Suburban	Body	Uplevel Radio																																																											
C	2014	Suburban	Body	Amplifier																																																											
C	2014	Suburban	Body	Rear Audio Control Module																																																											
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																											
C	2014	Suburban	Body	Personal Audio Link Control Module																																																											
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																											
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																	V									
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																	V									
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																											
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																											
C	2014	Suburban	Body	Liftgate Control Module																																																				V	V	V	V				
C	2014	Suburban	Body	Seat Memory Control Module																																																							V	V
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2014	Suburban	Body	Assist Step Control Module																																																												
C	2014	Suburban	Body	Right Side Object Detection Control Module																																																												
C	2014	Suburban	Body	Left Side Object Detection Control Module																																																												
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																												
C	2014	Suburban	Body	Parking Assist Control Module																																																												
C	2014	Suburban	Body	Theft Deterrent Module																																																												
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																												
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																												
C	2014	Tahoe	Chassis	Suspension Control Module																																																												
C	2014	Tahoe	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																												
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Tahoe	Body	Passenger Presence Module																																																V												
C	2014	Tahoe	Body	Instrument Cluster																																																												
C	2014	Tahoe	Body	Base Radio																																																												
C	2014	Tahoe	Body	Navigation Radio																																																												
C	2014	Tahoe	Body	Uplevel Radio																																																												
C	2014	Tahoe	Body	Amplifier																																																												
C	2014	Tahoe	Body	Rear Audio Control Module																																																												
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																												
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																												
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																	V											
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																	V											
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																												
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																												
C	2014	Tahoe	Body	Liftgate Control Module																																																			V	V	V	V						
C	2014	Tahoe	Body	Seat Memory Control Module																																																									V	V		
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																																												
C	2014	Tahoe	Body	Assist Step Control Module																																																												
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																																												
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																																												
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																												
C	2014	Tahoe	Body	Parking Assist Control Module																																																												
C	2014	Tahoe	Body	Theft Deterrent Module																																																												
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																												
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																												
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																												
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2015	Captiva (3GN)	Body	Body Control Module																																					V	V	V	V	V	V	V	V	V	V	V										
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																																V									
C	2015	Captiva (3GN)	Body	Instrument Cluster																																																									
C	2015	Captiva (3GN)	Body	Radio																																																									
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																									
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																									
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																									
C	2015	Captiva (3GN)	Body	HVAC Control Module																																																		V	V							
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																									
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																									
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																									
C	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																									
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																									
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																									
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																									
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																									
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																									
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																									
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																									
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																					V								V	V									
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																					V								V	V									
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																									
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	Captiva (Other)	Body	Instrument Cluster																																																									
C	2015	Captiva (Other)	Body	Headlamp Control Module																																																									
C	2015	Captiva (Other)	Body	HVAC Control Module																																																									
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																									
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																									
C	2015	Captiva (Other)	Body	Theft Deterrent Module																																																									
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																									
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																									

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																														
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																														
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																														
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																														
C	2015	Cheyenne	Chassis	Power Steering Control Module																																																														
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																														
C	2015	Cheyenne	Chassis	Suspension Control Module																																																														
C	2015	Cheyenne	Body	Body Control Module																																					V																									
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2015	Cheyenne	Body	Passenger Presence Module																																																														
C	2015	Cheyenne	Body	Instrument Cluster																																																														
C	2015	Cheyenne	Body	Radio Controls																																																														
C	2015	Cheyenne	Body	HVAC Controls																																																														
C	2015	Cheyenne	Body	Radio																																																														
C	2015	Cheyenne	Body	Amplifier																																																														
C	2015	Cheyenne	Body	Media Disc Player																																																														
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																														
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																														
C	2015	Cheyenne	Body	HVAC Control Module																																																														
C	2015	Cheyenne	Body	Parking Assist Control Module																																																														
C	2015	Cheyenne	Body	Frontview Camera Module																																																														
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																														
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																														
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																														
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																														
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																														
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																														
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
C	2015	Silverado	Chassis	Electronic Brake Control Module																																																														
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																														
C	2015	Silverado	Chassis	Power Steering Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Silverado	Chassis	Suspension Control Module																																																												
C	2015	Silverado	Body	Body Control Module																																					V																							
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Silverado	Body	Passenger Presence Module																																																												
C	2015	Silverado	Body	Instrument Cluster																																																											
C	2015	Silverado	Body	Radio Controls																																																											
C	2015	Silverado	Body	HVAC Controls																																																											
C	2015	Silverado	Body	Radio																																																											
C	2015	Silverado	Body	Amplifier																																																											
C	2015	Silverado	Body	Media Disc Player																																																											
C	2015	Silverado	Body	Human Machine Interface Control Module																																																											
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																											
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
C	2015	Silverado	Body	Parking Assist Control Module																																																											
C	2015	Silverado	Body	Frontview Camera Module																																																											
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																											
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2015	Suburban	Chassis	Electronic Brake Control Module																																																											
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																											
C	2015	Suburban	Chassis	Parking Brake Control Module																																																											
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2015	Suburban	Chassis	Power Steering Control Module																																																											
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Suburban	Chassis	Suspension Control Module																																																											
C	2015	Suburban	Body	Body Control Module																																																											
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Suburban	Body	Passenger Presence Module																																																											
C	2015	Suburban	Body	Instrument Cluster																																																											
C	2015	Suburban	Body	Radio Controls																																																											
C	2015	Suburban	Body	HVAC Controls																																																											
C	2015	Suburban	Body	Radio																																																											
C	2015	Suburban	Body	Amplifier																																																											
C	2015	Suburban	Body	Media Disc Player																																																											
C	2015	Suburban	Body	Human Machine Interface Control Module																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2015	Suburban	Body	HVAC Control Module																																																											
C	2015	Suburban	Body	Liftgate Control Module																																																						V	V	V	V			
C	2015	Suburban	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2015	Suburban	Body	Assist Step Control Module																																																														
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																														
C	2015	Suburban	Body	Parking Assist Control Module																																																														
C	2015	Suburban	Body	Frontview Camera Module																																																														
C	2015	Suburban	Body	Steering Column Lock Control Module																																																														
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																														
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																														
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																														
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																														
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																														
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																														
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																														
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																														
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																														
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																																														
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																														
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																														
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																														
C	2015	Tahoe	Chassis	Power Steering Control Module																																																														
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																														
C	2015	Tahoe	Chassis	Suspension Control Module																																																														
C	2015	Tahoe	Body	Body Control Module																																																														
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2015	Tahoe	Body	Passenger Presence Module																																																														
C	2015	Tahoe	Body	Instrument Cluster																																																														
C	2015	Tahoe	Body	Radio Controls																																																														
C	2015	Tahoe	Body	HVAC Controls																																																														
C	2015	Tahoe	Body	Radio																																																														
C	2015	Tahoe	Body	Amplifier																																																														
C	2015	Tahoe	Body	Media Disc Player																																																														
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																														
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																														
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																														
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																														
C	2015	Tahoe	Body	HVAC Control Module																																																														
C	2015	Tahoe	Body	Liftgate Control Module																																																									V	V	V	V		
C	2015	Tahoe	Body	Keyless Entry Control Module																																																														
C	2015	Tahoe	Body	Assist Step Control Module																																																														
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																														
C	2015	Tahoe	Body	Parking Assist Control Module																																																														
C	2015	Tahoe	Body	Frontview Camera Module																																																														
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																														
C	2015	Tahoe	Body	Battery Energy Control Module																																																														
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																														
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																														
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																											
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																											
C	2016	Captiva (3GN)	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																											
C	2016	Captiva (3GN)	Body	Radio																																																											
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																											
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																											
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																				V	V							
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																											
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																											
C	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																											
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																											
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																				V								V	V											
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																				V								V	V											
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Captiva (Other)	Body	Instrument Cluster																																																											
C	2016	Captiva (Other)	Body	Headlamp Control Module																																																											
C	2016	Captiva (Other)	Body	Radio																																																											
C	2016	Captiva (Other)	Body	HVAC Control Module																																																											
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																											
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																											
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
C	2016	Captiva (Other)	Body	Theft Deterrent Module																																																											
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																													
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																													
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																													
C	2016	Cheyenne	Chassis	Power Steering Control Module																																																													
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2016	Cheyenne	Chassis	Suspension Control Module																																																													
C	2016	Cheyenne	Body	Body Control Module																																																													
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	Cheyenne	Body	Passenger Presence Module																																																													
C	2016	Cheyenne	Body	Instrument Cluster																																																													
C	2016	Cheyenne	Body	Radio Controls																																																													
C	2016	Cheyenne	Body	HVAC Controls																																																													
C	2016	Cheyenne	Body	Radio																																																													
C	2016	Cheyenne	Body	Amplifier																																																													
C	2016	Cheyenne	Body	Media Disc Player																																																													
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																													
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																													
C	2016	Cheyenne	Body	HVAC Control Module																																																													
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																													
C	2016	Cheyenne	Body	Parking Assist Control Module																																																													
C	2016	Cheyenne	Body	Frontview Camera Module																																																													
C	2016	Cheyenne	Body	Frontview Camera Module																																																													
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																													
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																													
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																													
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																													
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																													
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																													
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																													
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																													
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																													
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																													
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																													
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																													
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																													
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																													
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																													
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																													
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																													
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																													
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																													
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																													
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																													
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
C	2016	Silverado	Chassis	Electronic Brake Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2016	Silverado	Chassis	Power Steering Control Module																																																													
C	2016	Silverado	Chassis	Power Steering Control Module																																																													
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2016	Silverado	Chassis	Suspension Control Module																																																													
C	2016	Silverado	Body	Body Control Module																																																												
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	Silverado	Body	Passenger Presence Module																																																													
C	2016	Silverado	Body	Instrument Cluster																																																													
C	2016	Silverado	Body	Radio Controls																																																												
C	2016	Silverado	Body	HVAC Controls																																																												
C	2016	Silverado	Body	Radio (IO3)																																																												
C	2016	Silverado	Body	Radio (IOB)																																																												
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																												
C	2016	Silverado	Body	Amplifier																																																												
C	2016	Silverado	Body	Media Disc Player																																																												
C	2016	Silverado	Body	Human Machine Interface Control Module																																																												
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																												
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																												
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																												
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																												
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																												
C	2016	Silverado	Body	Parking Assist Control Module																																																												
C	2016	Silverado	Body	Frontview Camera Module																																																												
C	2016	Silverado	Body	Frontview Camera Module																																																												
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2016	Suburban	Chassis	Electronic Brake Control Module																																																												
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																												
C	2016	Suburban	Chassis	Parking Brake Control Module																																																												
C	2016	Suburban	Chassis	Power Steering Control Module																																																												
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2016	Suburban	Chassis	Suspension Control Module																																																												
C	2016	Suburban	Body	Body Control Module																																																												
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Suburban	Body	Passenger Presence Module																																																												
C	2016	Suburban	Body	Instrument Cluster																																																												
C	2016	Suburban	Body	Radio Controls																																																											
C	2016	Suburban	Body	HVAC Controls																																																											
C	2016	Suburban	Body	Radio																																																											
C	2016	Suburban	Body	Amplifier																																																											
C	2016	Suburban	Body	Media Disc Player																																																											
C	2016	Suburban	Body	Human Machine Interface Control Module																																																											
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																																											
C	2016	Suburban	Body	HVAC Control Module																																																											
C	2016	Suburban	Body	Liftgate Control Module																																																						V	V	V	V		

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																													
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																													
C	2016	Suburban	Body	Keyless Entry Control Module																																																													
C	2016	Suburban	Body	Assist Step Control Module																																																													
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																													
C	2016	Suburban	Body	Parking Assist Control Module																																																													
C	2016	Suburban	Body	Frontview Camera Module																																																													
C	2016	Suburban	Body	Steering Column Lock Control Module																																																													
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																																													
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																													
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																													
C	2016	Tahoe	Chassis	Power Steering Control Module																																																													
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2016	Tahoe	Chassis	Suspension Control Module																																																													
C	2016	Tahoe	Body	Body Control Module																																																													
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	Tahoe	Body	Passenger Presence Module																																																													
C	2016	Tahoe	Body	Instrument Cluster																																																													
C	2016	Tahoe	Body	Radio Controls																																																													
C	2016	Tahoe	Body	HVAC Controls																																																													
C	2016	Tahoe	Body	Radio																																																													
C	2016	Tahoe	Body	Amplifier																																																													
C	2016	Tahoe	Body	Media Disc Player																																																													
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																													
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																													
C	2016	Tahoe	Body	HVAC Control Module																																																													
C	2016	Tahoe	Body	Liftgate Control Module																																																								V	V	V	V		
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																													
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																													
C	2016	Tahoe	Body	Keyless Entry Control Module																																																													
C	2016	Tahoe	Body	Assist Step Control Module																																																													
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																													
C	2016	Tahoe	Body	Parking Assist Control Module																																																													
C	2016	Tahoe	Body	Frontview Camera Module																																																													
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																													
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																													
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																													
E	2004	ALL	Chassis	Electronic Brake Control Module																																																													
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																													
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																													
E	2006	ALL	Chassis	Electronic Brake Control Module																																																													
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																													
E	2007	ALL	Chassis	Electronic Brake Control Module																																																													
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																															
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																															
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																															
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																															
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																															
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																															
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																															
G	2004	Express/Savana	Chassis	VSES																																																															
G	2004	Express/Savana	Body	Body Control Module																																																															
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																															
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																															
G	2004	Express/Savana	Body	OnStar																																																															
G	2004	Express/Savana	Body	Base Radio																																																															
G	2004	Express/Savana	Body	Uplevel Radio																																																															
G	2004	Express/Savana	Body	Remote Function Actuation																																																															
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																															
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																															
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																															
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																															
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																															
G	2004	Express Access/Savana Pro	Chassis	VSES																																																															
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																															
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																															
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																															
G	2004	Express Access/Savana Pro	Body	OnStar																																																															
G	2004	Express Access/Savana Pro	Body	Base Radio																																																															
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																															
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																															
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																															
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																															
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																															
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																															
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																															
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																													
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																													
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																													
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																													
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																													
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																													
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																													
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																													
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																													
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																													
G	2005	Express/Savana	Chassis	VSES																																																													
G	2005	Express/Savana	Body	Body Control Module																																																													
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																													
G	2005	Express/Savana	Body	Base Radio																																																													
G	2005	Express/Savana	Body	Uplevel Radio																																																													
G	2005	Express/Savana	Body	Remote Function Actuation																																																													
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																													
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																													
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																													
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																													
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																													
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																													
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																													
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																													
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																													
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																													
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																													
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																													
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																													
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																													
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																													
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																													
G	2005	Express Access/Savana Pro	Chassis	VSES																																																													
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																													
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																													
G	2005	Express Access/Savana Pro	Body	Base Radio																																																													
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																													
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																													
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																													
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																													
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																													
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																													
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																														
G	2006	Express/Savana	Chassis	VSES																																																														
G	2006	Express/Savana	Body	Body Control Module																																																														
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																														
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																														
G	2006	Express/Savana	Body	Passenger Presence System																																																														
G	2006	Express/Savana	Body	Base Radio																																																														
G	2006	Express/Savana	Body	Uplevel Radio																																																														
G	2006	Express/Savana	Body	Remote Function Actuation																																																														
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																														
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																														
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																														
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																														
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																														
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																														
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																														
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																														
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																														
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																														
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																														
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																														
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																														
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																														
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																														
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																														
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																														
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																														
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																														
G	2006	Express Access/Savana Pro	Chassis	VSES																																																														
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																														
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																														
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																														
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																														
G	2006	Express Access/Savana Pro	Body	Base Radio																																																														
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																														
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																														
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																												
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																												
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2007	Express/Savana	Body	Body Control Module																																																												
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																												
G	2007	Express/Savana	Body	Passenger Presence System																																																												
G	2007	Express/Savana	Body	Base Radio																																																												
G	2007	Express/Savana	Body	Uplevel Radio																																																												
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																													
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																													
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																												
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2007	Express Access/Savana Pro	Body	Radio																																																												
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2008	Express/Savana	Body	Body Control Module																																																												
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2008	Express/Savana	Body	Passenger Presence System																																																												
G	2008	Express/Savana	Body	Radio																																																											
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2008	Express/Savana	Body	Rollover Sensor																																																												
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2008	Express/Savana	Body	Theft Deterrent Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																														
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																													
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																													
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																													
G	2008	Express Access/Savana Pro	Body	Radio																																																													
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																													
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																													
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																													
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module										V																																																			
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																			
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module										V																																																			
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																														
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																														
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module										V																																																			
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																														
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																														
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																														
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																														
G	2009	Express/Savana	Body	Body Control Module																																																													
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2009	Express/Savana	Body	Passenger Presence System																																																													
G	2009	Express/Savana	Body	Radio																																																													
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
G	2009	Express/Savana	Body	Rollover Sensor																																																													
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
G	2009	Express/Savana	Body	Theft Deterrent Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module										V																																																			
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																			
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module										V																																																			
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module										V																																																			
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2009	Express Access/Savana Pro	Body	Radio																																																												
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																	
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express/Savana	Body	Body Control Module																																																												
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2010	Express/Savana	Body	Passenger Presence System																																																												
G	2010	Express/Savana	Body	Radio																																																											
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2010	Express/Savana	Body	Rollover Sensor																																																											
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2010	Express/Savana	Body	Theft Deterrent Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																	
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																													
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																													
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																													
G	2010	Express Access/Savana Pro	Body	Radio																																																													
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																													
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																													
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																													
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																													
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																													
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																		
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																													
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2011	Express/Savana	Body	Body Control Module																																																													
G	2011	Express/Savana	Body	Digital Radio Receiver																																																													
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2011	Express/Savana	Body	Passenger Presence System																																																													
G	2011	Express/Savana	Body	Radio																																																													
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
G	2011	Express/Savana	Body	Rollover Sensor																																																													
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
G	2011	Express/Savana	Body	Theft Deterrent Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																		
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2011	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2011	Express Access/Savana Pro	Body	Radio																																																												
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																		
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2012	Express/Savana	Body	Body Control Module																																																												
G	2012	Express/Savana	Body	Digital Radio Receiver																																																												
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2012	Express/Savana	Body	Passenger Presence System																																																												
G	2012	Express/Savana	Body	Radio																																																												
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2012	Express/Savana	Body	Rollover Sensor																																																												
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2012	Express/Savana	Body	Theft Deterrent Module																																																												
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																		
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2012	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2012	Express Access/Savana Pro	Body	Radio																																																												
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																		
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2013	Express/Savana	Body	Body Control Module																																																												
G	2013	Express/Savana	Body	Digital Radio Receiver																																																												
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2013	Express/Savana	Body	Navigation Radio																																																												
G	2013	Express/Savana	Body	Park Assist Module																																																												
G	2013	Express/Savana	Body	Passenger Presence System																																																												
G	2013	Express/Savana	Body	Radio																																																												
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2013	Express/Savana	Body	Rollover Sensor																																																												
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2013	Express/Savana	Body	Theft Deterrent Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2013	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2013	Express Access/Savana Pro	Body	Radio																																																										
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2014	Express	Chassis	Electronic Brake Control Module																																																										
G	2014	Express	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V	V												
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2014	Express	Body	Passenger Presence Module																																																V										
G	2014	Express	Body	Rollover Sensor Module																																																										
G	2014	Express	Body	Instrument Cluster																																																										
G	2014	Express	Body	Chime Alarm Control Module																																																										
G	2014	Express	Body	Base Radio																																																										
G	2014	Express	Body	Navigation Radio																																																										
G	2014	Express	Body	Uplevel Radio																																																										
G	2014	Express	Body	Digital Radio Receiver Control Module																																																										
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2014	Express	Body	Auxiliary Heater Control Module																																																										
G	2014	Express	Body	Remote Control Door Lock Receiver																																																										
G	2014	Express	Body	Parking Assist Control Module																																																										
G	2014	Express	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2014	Savana	Chassis	Electronic Brake Control Module																																																										
G	2014	Savana	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2014	Savana	Body	Passenger Presence Module																																															V											
G	2014	Savana	Body	Rollover Sensor Module																																																										
G	2014	Savana	Body	Instrument Cluster																																																										
G	2014	Savana	Body	Chime Alarm Control Module																																																										
G	2014	Savana	Body	Base Radio																																																										
G	2014	Savana	Body	Navigation Radio																																																										
G	2014	Savana	Body	Uplevel Radio																																																										
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2014	Savana	Body	Auxiliary Heater Control Module																																																										
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
G	2014	Savana	Body	Parking Assist Control Module																																																										
G	2014	Savana	Body	Theft Deterrent Module																																																										
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2015	Express	Chassis	Electronic Brake Control Module																																																										
G	2015	Express	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V												
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2015	Express	Body	Rollover Sensor Module																																																										
G	2015	Express	Body	Instrument Cluster																																																										
G	2015	Express	Body	Digital Radio Receiver Control Module																																																										
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2015	Express	Body	Auxiliary Heater Control Module																																																										
G	2015	Express	Body	Remote Control Door Lock Receiver																																																										
G	2015	Express	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2015	Express	Body	Theft Deterrent Module																																																											
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
G	2015	Savana	Chassis	Electronic Brake Control Module																																																											
G	2015	Savana	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
G	2015	Savana	Body	Rollover Sensor Module																																																											
G	2015	Savana	Body	Instrument Cluster																																																										
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2015	Savana	Body	Auxiliary Heater Control Module																																																										
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
G	2015	Savana	Body	Parking Assist Control Module																																																										
G	2015	Savana	Body	Theft Deterrent Module																																																										
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2016	Express	Chassis	Electronic Brake Control Module																																																										
G	2016	Express	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
G	2016	Express	Body	Instrument Cluster																																																										
G	2016	Express	Body	Chime Alarm Control Module																																																										
G	2016	Express	Body	Base Radio																																																										
G	2016	Express	Body	Navigation Radio																																																									
G	2016	Express	Body	Uplevel Radio																																																									
G	2016	Express	Body	Digital Radio Receiver Control Module																																																										
G	2016	Express	Body	Telematics Communication Interface Control Module																																																										
G	2016	Express	Body	Auxiliary Heater Control Module																																																										
G	2016	Express	Body	Remote Control Door Lock Receiver																																																										
G	2016	Express	Body	Parking Assist Control Module																																																										
G	2016	Express	Body	Theft Deterrent Module																																																										
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
G	2016	Savana	Chassis	Electronic Brake Control Module																																																												
G	2016	Savana	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V														
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2016	Savana	Body	Instrument Cluster																																																												
G	2016	Savana	Body	Chime Alarm Control Module																																																												
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																												
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																												
G	2016	Savana	Body	Auxiliary Heater Control Module																																																												
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																												
G	2016	Savana	Body	Parking Assist Control Module																																																												
G	2016	Savana	Body	Theft Deterrent Module																																																												
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																												
H	2004	Express/Savana	Chassis	VSES																																																												
H	2004	Express/Savana	Body	Body Control Module																																																												
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																												
H	2004	Express/Savana	Body	OnStar																																																												
H	2004	Express/Savana	Body	Base Radio																																																												
H	2004	Express/Savana	Body	Uplevel Radio																																																												
H	2004	Express/Savana	Body	Remote Function Actuation																																																												
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2004	Express Access/Savana Pro	Chassis	VSES																																																												
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2004	Express Access/Savana Pro	Body	OnStar																																																												
H	2004	Express Access/Savana Pro	Body	Base Radio																																																												
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																												
H	2005	Express/Savana	Chassis	VSES																																																												
H	2005	Express/Savana	Body	Body Control Module																																																												
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																												
H	2005	Express/Savana	Body	Base Radio																																																												
H	2005	Express/Savana	Body	Uplevel Radio																																																												
H	2005	Express/Savana	Body	Remote Function Actuation																																																												
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																														
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																														
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																														
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																														
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																														
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																														
H	2005	Express Access/Savana Pro	Chassis	VSES																																																														
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																														
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																														
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																														
H	2005	Express Access/Savana Pro	Body	Base Radio																																																														
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																														
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																														
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																														
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																														
H	2006	Express/Savana	Chassis	VSES																																																														
H	2006	Express/Savana	Body	Body Control Module																																																														
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																														
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																														
H	2006	Express/Savana	Body	Passenger Presence System																																																														
H	2006	Express/Savana	Body	Base Radio																																																														
H	2006	Express/Savana	Body	Uplevel Radio																																																														
H	2006	Express/Savana	Body	Remote Function Actuation																																																														
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																														
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																														
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																														
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																														
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																														
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																														
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																														
H	2006	Express Access/Savana Pro	Chassis	VSES																																																														
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																														
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																														
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																														
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																														
H	2006	Express Access/Savana Pro	Body	Base Radio																																																														
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																														
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																														
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																														
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																														
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																														
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																														
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																														
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																														
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2007	Express/Savana	Body	Body Control Module																																																											
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2007	Express/Savana	Body	Passenger Presence System																																																											
H	2007	Express/Savana	Body	Base Radio																																																											
H	2007	Express/Savana	Body	Uplevel Radio																																																											
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																											
H	2007	Express Access/Savana Pro	Body	Base Radio																																																											
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																											
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2008	Express/Savana	Body	Body Control Module																																																											
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2008	Express/Savana	Body	Passenger Presence System																																																											
H	2008	Express/Savana	Body	Radio																																																										
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
H	2008	Express/Savana	Body	Rollover Sensor																																																											
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2008	Express/Savana	Body	Theft Deterrent Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2008	Express Access/Savana Pro	Body	Radio																																																												
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module										V																																																		
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																		
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module										V																																																		
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module										V																																																		
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
H	2009	Express/Savana	Body	Body Control Module																																																												
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2009	Express/Savana	Body	Passenger Presence System																																																												
H	2009	Express/Savana	Body	Radio																																																												
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2009	Express/Savana	Body	Rollover Sensor																																																												
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2009	Express/Savana	Body	Theft Deterrent Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module										V																																																		
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																		
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module										V																																																		
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module										V																																																		
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2009	Express Access/Savana Pro	Body	Radio																																																												
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2010	Express/Savana	Body	Body Control Module																																																												
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2010	Express/Savana	Body	Passenger Presence System																																																												
H	2010	Express/Savana	Body	Radio																																																												
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2010	Express/Savana	Body	Rollover Sensor																																																												
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2010	Express/Savana	Body	Theft Deterrent Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2010	Express Access/Savana Pro	Body	Radio																																																												
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2011	Express/Savana	Body	Body Control Module																																																												
H	2011	Express/Savana	Body	Digital Radio Receiver																																																												
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2011	Express/Savana	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2011	Express/Savana	Body	Radio																																																												
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2011	Express/Savana	Body	Rollover Sensor																																																												
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2011	Express/Savana	Body	Theft Deterrent Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2011	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2011	Express Access/Savana Pro	Body	Radio																																																												
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2012	Express/Savana	Body	Body Control Module																																																												
H	2012	Express/Savana	Body	Digital Radio Receiver																																																												
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2012	Express/Savana	Body	Passenger Presence System																																																												
H	2012	Express/Savana	Body	Radio																																																												
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2012	Express/Savana	Body	Rollover Sensor																																																												
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2012	Express/Savana	Body	Theft Deterrent Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2012	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2012	Express Access/Savana Pro	Body	Radio																																																												
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2013	Express/Savana	Body	Body Control Module																																																												
H	2013	Express/Savana	Body	Digital Radio Receiver																																																												
H	2013	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2013	Express/Savana	Body	Navigation Radio																																																												
H	2013	Express/Savana	Body	Park Assist Module																																																												
H	2013	Express/Savana	Body	Passenger Presence System																																																												
H	2013	Express/Savana	Body	Radio																																																												
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2013	Express/Savana	Body	Rollover Sensor																																																												
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2013	Express/Savana	Body	Theft Deterrent Module																																																												
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2013	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2013	Express Access/Savana Pro	Body	Navigation Radio																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2013	Express Access/Savana Pro	Body	Radio																																																										
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2014	Express	Chassis	Electronic Brake Control Module																																																										
H	2014	Express	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V												
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Express	Body	Passenger Presence Module																																															V											
H	2014	Express	Body	Rollover Sensor Module																																																										
H	2014	Express	Body	Instrument Cluster																																																										
H	2014	Express	Body	Chime Alarm Control Module																																																										
H	2014	Express	Body	Base Radio																																																										
H	2014	Express	Body	Navigation Radio																																																										
H	2014	Express	Body	Uplevel Radio																																																										
H	2014	Express	Body	Digital Radio Receiver Control Module																																																										
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2014	Express	Body	Auxiliary Heater Control Module																																																										
H	2014	Express	Body	Remote Control Door Lock Receiver																																																										
H	2014	Express	Body	Parking Assist Control Module																																																										
H	2014	Express	Body	Theft Deterrent Module																																																										
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2014	Savana	Chassis	Electronic Brake Control Module																																																											
H	2014	Savana	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Savana	Body	Passenger Presence Module																																														V										
H	2014	Savana	Body	Rollover Sensor Module																																																									
H	2014	Savana	Body	Instrument Cluster																																																									
H	2014	Savana	Body	Chime Alarm Control Module																																																									
H	2014	Savana	Body	Base Radio																																																									
H	2014	Savana	Body	Navigation Radio																																																									
H	2014	Savana	Body	Uplevel Radio																																																									
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																									
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																									
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																									
H	2014	Savana	Body	Auxiliary Heater Control Module																																																									
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																									
H	2014	Savana	Body	Parking Assist Control Module																																																									
H	2014	Savana	Body	Theft Deterrent Module																																																									
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2015	Express	Chassis	Electronic Brake Control Module																																																									
H	2015	Express	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
H	2015	Express	Body	Rollover Sensor Module																																																									
H	2015	Express	Body	Instrument Cluster																																																								
H	2015	Express	Body	Digital Radio Receiver Control Module																																																									
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																									
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																									
H	2015	Express	Body	Auxiliary Heater Control Module																																																									
H	2015	Express	Body	Remote Control Door Lock Receiver																																																									
H	2015	Express	Body	Parking Assist Control Module																																																									
H	2015	Express	Body	Theft Deterrent Module																																																									
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2015	Savana	Chassis	Electronic Brake Control Module																																																									
H	2015	Savana	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2015	Savana	Body	Rollover Sensor Module																																																										
H	2015	Savana	Body	Instrument Cluster																																																										
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2015	Savana	Body	Auxiliary Heater Control Module																																																										
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2015	Savana	Body	Parking Assist Control Module																																																										
H	2015	Savana	Body	Theft Deterrent Module																																																										
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2016	Express	Chassis	Electronic Brake Control Module																																																										
H	2016	Express	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V											
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Express	Body	Instrument Cluster																																																										
H	2016	Express	Body	Chime Alarm Control Module																																																										
H	2016	Express	Body	Base Radio																																																										
H	2016	Express	Body	Navigation Radio																																																										
H	2016	Express	Body	Uplevel Radio																																																										
H	2016	Express	Body	Digital Radio Receiver Control Module																																																										
H	2016	Express	Body	Telematics Communication Interface Control Module																																																										
H	2016	Express	Body	Auxiliary Heater Control Module																																																										
H	2016	Express	Body	Remote Control Door Lock Receiver																																																										
H	2016	Express	Body	Parking Assist Control Module																																																										
H	2016	Express	Body	Theft Deterrent Module																																																										
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2016	Savana	Chassis	Electronic Brake Control Module																																																										
H	2016	Savana	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V											
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Savana	Body	Instrument Cluster																																																										
H	2016	Savana	Body	Chime Alarm Control Module																																																										
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
H	2016	Savana	Body	Auxiliary Heater Control Module																																																										
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2016	Savana	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2016	Savana	Body	Theft Deterrent Module																																																														
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																														
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																														
J	2004	ALL	Chassis	Electronic Brake Control Module																																																														
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																														
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																														
J	2007	ALL	Chassis	Electronic Brake Control Module																																																														
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																													
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																													
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																													
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																													
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																													
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																													
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																													
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																													
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																													
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																													
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																													
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																																													
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																																													
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																													
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																													
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																													
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																																													
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																													
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2013	Tracker	Chassis	Power Steering Control Module																																																													
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2013	Tracker	Body	Body Control Module																																																													
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2013	Tracker	Body	Passenger Presence Module																																																													
J	2013	Tracker	Body	Instrument Cluster																																																													
J	2013	Tracker	Body	Radio																																																												
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																																													
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																																													
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																																													
J	2013	Tracker	Body	Front Seat Heating Control Module																																																													
J	2013	Tracker	Body	Parking Assist Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2013	Tracker	Body	Frontview Camera Module																																																														
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																														
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																														
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																														
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																														
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																														
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																														
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																														
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																														
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																														
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																														
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																														
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																														
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																														
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																														
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																														
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																														
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																														
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																														
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																														
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																														
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																														
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																														
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																														
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																														
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																														
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																														
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																														
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																														
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																														
J	2013	Trax	Chassis	Electronic Brake Control Module																																																														
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																														
J	2013	Trax	Chassis	Power Steering Control Module																																																														
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																														
J	2013	Trax	Body	Body Control Module																																																														
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
J	2013	Trax	Body	Passenger Presence Module																																																														
J	2013	Trax	Body	Instrument Cluster																																																														
J	2013	Trax	Body	Radio																																																														
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																														
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																														
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																														
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																														
J	2013	Trax	Body	Front Seat Heating Control Module																																																														
J	2013	Trax	Body	Parking Assist Control Module																																																														
J	2013	Trax	Body	Frontview Camera Module																																																														
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																														
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																														
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																												
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																												
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																												
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																												
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																												
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																												
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																												
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																												
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																												
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																												
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																												
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																												
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																												
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																																												
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																												
J	2014	Tracker	Chassis	Power Steering Control Module																																																												
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Tracker	Body	Body Control Module																																																												
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Tracker	Body	Passenger Presence Module																																																												
J	2014	Tracker	Body	Instrument Cluster																																																												
J	2014	Tracker	Body	Radio																																																											
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																																												
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Tracker	Body	Front Seat Heating Control Module																																																												
J	2014	Tracker	Body	Parking Assist Control Module																																																												
J	2014	Tracker	Body	Frontview Camera Module																																																												
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																														
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																														
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																														
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																														
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																														
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																														
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																														
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																														
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																														
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																														
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																														
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																															
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																															
J	2014	Trax	Chassis	Electronic Brake Control Module																																																															
J	2014	Trax	Chassis	Power Steering Control Module																																																															
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																															
J	2014	Trax	Body	Body Control Module																																																															
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
J	2014	Trax	Body	Passenger Presence Module																																																															
J	2014	Trax	Body	Instrument Cluster																																																															
J	2014	Trax	Body	Radio																																																															
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																															
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																															
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																															
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																															
J	2014	Trax	Body	Front Seat Heating Control Module																																																															
J	2014	Trax	Body	Parking Assist Control Module																																																															
J	2014	Trax	Body	Frontview Camera Module																																																															
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																															
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																															
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																															
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																														
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																															
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																															
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																															
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																															
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																															
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																															
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																															
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																															
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																															
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																															
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																															
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																															
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																															
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																															
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																															
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																															
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																															
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																													
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																													
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																													
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																													
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																													
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																													
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																													
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																													
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																													
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																																													
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																													
J	2015	Tracker	Chassis	Power Steering Control Module																																																													
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2015	Tracker	Body	Body Control Module																																																													
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2015	Tracker	Body	Instrument Cluster																																																													
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																																													
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																																													
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																																													
J	2015	Tracker	Body	Front Seat Heating Control Module																																																													
J	2015	Tracker	Body	Parking Assist Control Module																																																													
J	2015	Tracker	Body	Frontview Camera Module																																																													
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																													
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																													
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																													
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																													
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																													
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																													
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																													
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																													
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																													
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																													
J	2015	Trax	Powertrain	Chassis Control Module																																																													
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																													
J	2015	Trax	Chassis	Electronic Brake Control Module																																																													
J	2015	Trax	Chassis	Power Steering Control Module																																																													
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2015	Trax	Body	Body Control Module																																																													
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2015	Trax	Body	Passenger Presence Module																																																													
J	2015	Trax	Body	Instrument Cluster																																																													
J	2015	Trax	Body	Radio																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																													
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																													
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																													
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																													
J	2015	Trax	Body	Seat Memory Control Module																																																													
J	2015	Trax	Body	Front Seat Heating Control Module																																																													
J	2015	Trax	Body	Right Side Object Detection Control Module																																																													
J	2015	Trax	Body	Left Side Object Detection Control Module																																																													
J	2015	Trax	Body	Parking Assist Control Module																																																													
J	2015	Trax	Body	Frontview Camera Module																																																													
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																													
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																													
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																													
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																													
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																													
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																													
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																													
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																													
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																													
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																													
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																													
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																													
J	2016	Tracker	Chassis	Power Steering Control Module																																																													
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2016	Tracker	Body	Body Control Module																																																													
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2016	Tracker	Body	Instrument Cluster																																																													
J	2016	Tracker	Body	Trailer Interface Control Module																																																													
J	2016	Tracker	Body	Radio																																																													
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																																													
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																																													
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																																													
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																																													
J	2016	Tracker	Body	Front Seat Heating Control Module																																																													
J	2016	Tracker	Body	Parking Assist Control Module																																																													
J	2016	Tracker	Body	Frontview Camera Module																																																													
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																													
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																													
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																													
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																													
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																													
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																													
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																													
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																													
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																													
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																													
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																													
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																													
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																													
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																													
J	2016	Trax	Powertrain	Chassis Control Module																																																													
J	2016	Trax	Chassis	Electronic Brake Control Module																																																													
J	2016	Trax	Chassis	Power Steering Control Module																																																													
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2016	Trax	Body	Body Control Module																																																													
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2016	Trax	Body	Passenger Presence Module																																																													
J	2016	Trax	Body	Instrument Cluster																																																													
J	2016	Trax	Body	Trailer Interface Control Module																																																													
J	2016	Trax	Body	Radio																																																												
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																												
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
J	2016	Trax	Body	Seat Memory Control Module																																																												
J	2016	Trax	Body	Front Seat Heating Control Module																																																												
J	2016	Trax	Body	Right Side Object Detection Control Module																																																												
J	2016	Trax	Body	Left Side Object Detection Control Module																																																												
J	2016	Trax	Body	Parking Assist Control Module																																																												
J	2016	Trax	Body	Frontview Camera Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																														
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																														
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																														
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																														
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																														
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																														
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																														
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																														
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																														
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																														
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																														
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																														
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																														
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																														
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																														
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																														
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																														
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																														
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																														
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																														
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																														
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																														
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																														
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																														
K	2004	ALL	Chassis	ESC																																																														
K	2004	ALL	Chassis	Rear Wheel Steering																																																														
K	2004	ALL	Chassis	Tire Pressure Monitor																																																														
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																														
K	2004	ALL	Chassis	VSES																																																														
K	2004	ALL	Body	Amplifier (Bose)																																																														
K	2004	ALL	Body	Body Control Module																																																														
K	2004	ALL	Body	CD Changer																																																														
K	2004	ALL	Body	Chime																																																														
K	2004	ALL	Body	Driver Door Module																																																														
K	2004	ALL	Body	Driver Seat Module																																																														
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																														
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																														
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																														
K	2004	ALL	Body	Instrument Panel Cluster																																																														
K	2004	ALL	Body	OnStar																																																														
K	2004	ALL	Body	Passenger Door Module																																																														
K	2004	ALL	Body	Passenger Presence System																																																														
K	2004	ALL	Body	Radio Base																																																														
K	2004	ALL	Body	Radio Uplevel																																																														
K	2004	ALL	Body	Radio Navigation																																																														
K	2004	ALL	Body	Rear Aux. Climate Module																																																														
K	2004	ALL	Body	Rear HVAC																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2004	ALL	Body	Rear Seat Audio																																																														
K	2004	ALL	Body	Rear Seat Entertainment																																																														
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2004	ALL	Body	Vehicle Theft Deterrent																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																														
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																														
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																														
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																														
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																														
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																														
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																											
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2005	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																													
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																													
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																													
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																													
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																													
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																													
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																													
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																													
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																													
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																													
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																													
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																													
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																													
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																													
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																													
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																													
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																													
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																													
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
K	2006	ALL	Chassis	ESC																																																												
K	2006	ALL	Chassis	Tire Pressure Monitor																																																												
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																												
K	2006	ALL	Chassis	VSES																																																												
K	2006	ALL	Body	Amplifier (Bose)																																																												
K	2006	ALL	Body	Body Control Module																																																												
K	2006	ALL	Body	CD Changer																																																												
K	2006	ALL	Body	Chime																																																												
K	2006	ALL	Body	Disc Player and Video Display																																																												
K	2006	ALL	Body	Driver Door Module																																																												
K	2006	ALL	Body	Driver Seat Module																																																												
K	2006	ALL	Body	Generator Battery Control Module																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2006	ALL	Body	Instrument Panel Cluster																																																												
K	2006	ALL	Body	Passenger Door Module																																																												
K	2006	ALL	Body	Passenger Presence System																																																												
K	2006	ALL	Body	Base Radio																																																												
K	2006	ALL	Body	Uplevel Radio																																																												
K	2006	ALL	Body	Navigation Radio																																																												
K	2006	ALL	Body	Rear Aux. Climate Module																																																												
K	2006	ALL	Body	Rear HVAC																																																												
K	2006	ALL	Body	Rear Seat Audio																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2006	ALL	Body	Vehicle Theft Deterrent																																																												
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Avalanche	Chassis	Electronic Suspension Control																																																												
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																																												
K	2007	Avalanche	Body	Amplifier (Bose)																																																												
K	2007	Avalanche	Body	Assist Step Controller																																																												
K	2007	Avalanche	Body	Body Control Module																																																												
K	2007	Avalanche	Body	Body Control Module (aux.)																																																												
K	2007	Avalanche	Body	Digital Radio Receiver																																																												
K	2007	Avalanche	Body	Driver Door Switch																																																												
K	2007	Avalanche	Body	HVAC Control Module Auto																																																												
K	2007	Avalanche	Body	HVAC Control Module Manual																																																												
K	2007	Avalanche	Body	Instrument Panel Cluster																																																												
K	2007	Avalanche	Body	Memory Seat Module																																																												
K	2007	Avalanche	Body	Park Assist Module																																																												
K	2007	Avalanche	Body	Passenger Door Switch																																																												
K	2007	Avalanche	Body	Passenger Presence System																																																												
K	2007	Avalanche	Body	Radio																																																											
K	2007	Avalanche	Body	Rear Heated Seat Module																																																												
K	2007	Avalanche	Body	Rear HVAC/RSA																																																												
K	2007	Avalanche	Body	Rollover Sensor																																																												
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																												
K	2007	Avalanche	Body	Theft Deterrent Module																																																												
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																													
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																													
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																													
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2007	Suburban	Chassis	Electronic Suspension Control																																																													
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																												
K	2007	Suburban	Body	Amplifier (Bose)																																																												
K	2007	Suburban	Body	Assist Step Controller																																																												
K	2007	Suburban	Body	Body Control Module																																																											
K	2007	Suburban	Body	Body Control Module (aux.)																																																											
K	2007	Suburban	Body	Digital Radio Receiver																																																											
K	2007	Suburban	Body	Driver Door Switch																																																											
K	2007	Suburban	Body	HVAC Control Module Auto																																																											
K	2007	Suburban	Body	HVAC Control Module Manual																																																											
K	2007	Suburban	Body	Instrument Panel Cluster																																																											
K	2007	Suburban	Body	Lift Gate Module																									V	V																																
K	2007	Suburban	Body	Memory Seat Module																																																										
K	2007	Suburban	Body	Park Assist Module																																																										
K	2007	Suburban	Body	Passenger Door Switch																																																										
K	2007	Suburban	Body	Passenger Presence System																																																										
K	2007	Suburban	Body	Radio																																																									
K	2007	Suburban	Body	Rear Heated Seat Module																																																										
K	2007	Suburban	Body	Rear HVAC/RSA																																																										
K	2007	Suburban	Body	Rollover Sensor																																																										
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2007	Suburban	Body	Theft Deterrent Module																																																										
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																													
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																													
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																													
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																													
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																													
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																													
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																													
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2007	Silverado	Chassis	Electronic Suspension Control																																																													
K	2007	Silverado	Chassis	Trailer Brake Control Module																																																													
K	2007	Silverado	Body	Amplifier (Bose)																																																													
K	2007	Silverado	Body	Body Control Module																																																													
K	2007	Silverado	Body	Body Control Module (aux.)																																																													
K	2007	Silverado	Body	Digital Radio Receiver																																																													
K	2007	Silverado	Body	Driver Door Switch																																																													
K	2007	Silverado	Body	HVAC Control Module Auto																																																													
K	2007	Silverado	Body	HVAC Control Module Manual																																																													
K	2007	Silverado	Body	Instrument Panel Cluster																																																													
K	2007	Silverado	Body	Memory Seat Module																																																													
K	2007	Silverado	Body	Park Assist Module																																																													
K	2007	Silverado	Body	Passenger Door Switch																																																													
K	2007	Silverado	Body	Passenger Presence System																																																													
K	2007	Silverado	Body	Radio																																																													
K	2007	Silverado	Body	Rear Heated Seat Module																																																													
K	2007	Silverado	Body	Rear HVAC/RSA																																																													
K	2007	Silverado	Body	Rollover Sensor																																																													
K	2007	Silverado	Body	Supplemental Inflatable Restraint																																																													
K	2007	Silverado	Body	Theft Deterrent Module																																																													
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																													
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																												
K	2007	Tahoe	Body	Amplifier (Bose)																																																												
K	2007	Tahoe	Body	Assist Step Controller																																																												
K	2007	Tahoe	Body	Body Control Module																																																												
K	2007	Tahoe	Body	Body Control Module (aux.)																																																												
K	2007	Tahoe	Body	Digital Radio Receiver																																																												
K	2007	Tahoe	Body	Driver Door Switch																																																												
K	2007	Tahoe	Body	HVAC Control Module Auto																																																												
K	2007	Tahoe	Body	HVAC Control Module Manual																																																												
K	2007	Tahoe	Body	Instrument Panel Cluster																																																												
K	2007	Tahoe	Body	Lift Gate Module																									V	V																																		
K	2007	Tahoe	Body	Memory Seat Module																																																												
K	2007	Tahoe	Body	Park Assist Module																																																												
K	2007	Tahoe	Body	Passenger Door Switch																																																												
K	2007	Tahoe	Body	Passenger Presence System																																																												
K	2007	Tahoe	Body	Radio																																																												
K	2007	Tahoe	Body	Rear Heated Seat Module																																																												
K	2007	Tahoe	Body	Rear HVAC/RSA																																																												
K	2007	Tahoe	Body	Rollover Sensor																																																												
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2007	Tahoe	Body	Theft Deterrent Module																																																												
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2008	Avalanche	Chassis	Electronic Brake Control Module			V																																																									
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																												
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																												
K	2008	Avalanche	Body	Amplifier (Bose)																																																												
K	2008	Avalanche	Body	Assist Step Controller																																																												
K	2008	Avalanche	Body	Body Control Module																																																												
K	2008	Avalanche	Body	Body Control Module (aux.)																																																												
K	2008	Avalanche	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2008	Avalanche	Body	Driver Door Switch																																																														
K	2008	Avalanche	Body	HVAC Control Module Auto																																																														
K	2008	Avalanche	Body	HVAC Control Module Manual																																																														
K	2008	Avalanche	Body	Instrument Panel Cluster																																																														
K	2008	Avalanche	Body	Memory Seat Module																																																														
K	2008	Avalanche	Body	Park Assist Module																																																														
K	2008	Avalanche	Body	Passenger Door Switch																																																														
K	2008	Avalanche	Body	Passenger Presence System																																																														
K	2008	Avalanche	Body	Radio																																																														
K	2008	Avalanche	Body	Rear Heated Seat Module																																																														
K	2008	Avalanche	Body	Rear HVAC/RSA																																																														
K	2008	Avalanche	Body	Rollover Sensor																																																														
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																														
K	2008	Avalanche	Body	Theft Deterrent Module																																																														
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																														
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																														
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																														
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																														
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																														
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																														
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																														
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																														
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																														
K	2008	Suburban	Chassis	EBCM Under 8600 GVW			V																																																											
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																														
K	2008	Suburban	Chassis	Electronic Suspension Control																																																														
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																														
K	2008	Suburban	Body	Amplifier (Bose)																																																														
K	2008	Suburban	Body	Assist Step Controller																																																														
K	2008	Suburban	Body	Body Control Module																																																														
K	2008	Suburban	Body	Body Control Module (aux.)																																																														
K	2008	Suburban	Body	Digital Radio Receiver																																																														
K	2008	Suburban	Body	Driver Door Switch																																																														
K	2008	Suburban	Body	HVAC Control Module Auto																																																														
K	2008	Suburban	Body	HVAC Control Module Manual																																																														
K	2008	Suburban	Body	Instrument Panel Cluster																																																														
K	2008	Suburban	Body	Lift Gate Module																									V	V																																			
K	2008	Suburban	Body	Memory Seat Module																																																														
K	2008	Suburban	Body	Park Assist Module																																																														
K	2008	Suburban	Body	Passenger Door Switch																																																														
K	2008	Suburban	Body	Passenger Presence System																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2008	Suburban	Body	Radio																																																											
K	2008	Suburban	Body	Rear Heated Seat Module																																																											
K	2008	Suburban	Body	Rear HVAC/RSA																																																											
K	2008	Suburban	Body	Rollover Sensor																																																											
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																																											
K	2008	Suburban	Body	Theft Deterrent Module																																																											
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES			V																																																								
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2008	Silverado	Chassis	Electronic Suspension Control																																																											
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																											
K	2008	Silverado	Body	Amplifier (Bose)																																																											
K	2008	Silverado	Body	Body Control Module																																																											
K	2008	Silverado	Body	Body Control Module (aux.)																																																											
K	2008	Silverado	Body	Digital Radio Receiver																																																											
K	2008	Silverado	Body	Driver Door Switch																																																											
K	2008	Silverado	Body	HVAC Control Module Auto																																																											
K	2008	Silverado	Body	HVAC Control Module Manual																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2008	Silverado	Body	Instrument Panel Cluster																																																											
K	2008	Silverado	Body	Memory Seat Module																																																											
K	2008	Silverado	Body	Park Assist Module																																																											
K	2008	Silverado	Body	Passenger Door Switch																																																											
K	2008	Silverado	Body	Passenger Presence System																																																											
K	2008	Silverado	Body	Radio																																																											
K	2008	Silverado	Body	Rear Heated Seat Module																																																											
K	2008	Silverado	Body	Rear HVAC/RSA																																																											
K	2008	Silverado	Body	Rollover Sensor																																																											
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																																											
K	2008	Silverado	Body	Theft Deterrent Module																																																											
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
K	2008	Tahoe	Chassis	Electronic Brake Control Module			V																																																								
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																											
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																											
K	2008	Tahoe	Body	Amplifier (Bose)																																																											
K	2008	Tahoe	Body	Assist Step Controller																																																											
K	2008	Tahoe	Body	Body Control Module																																																											
K	2008	Tahoe	Body	Body Control Module (aux.)																																																											
K	2008	Tahoe	Body	Digital Radio Receiver																																																											
K	2008	Tahoe	Body	Driver Door Switch																																																											
K	2008	Tahoe	Body	HVAC Control Module Auto																																																											
K	2008	Tahoe	Body	HVAC Control Module Manual																																																											
K	2008	Tahoe	Body	Instrument Panel Cluster																																																											
K	2008	Tahoe	Body	Lift Gate Module																									V	V																																	
K	2008	Tahoe	Body	Memory Seat Module																																																											
K	2008	Tahoe	Body	Park Assist Module																																																											
K	2008	Tahoe	Body	Passenger Door Switch																																																											
K	2008	Tahoe	Body	Passenger Presence System																																																											
K	2008	Tahoe	Body	Radio																																																											
K	2008	Tahoe	Body	Rear Heated Seat Module																																																											
K	2008	Tahoe	Body	Rear HVAC/RSA																																																											
K	2008	Tahoe	Body	Rollover Sensor																																																											
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																											
K	2008	Tahoe	Body	Theft Deterrent Module																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2008	Tahoe Hybrid	Body	Lift Gate Module																									V	V																																
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2008	Tahoe Hybrid	Body	Body Control Module																																																										
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2008	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2008	Tahoe Hybrid	Body	Lift Gate Module																									V	V																																
K	2008	Tahoe Hybrid	Body	Memory Seat Module																																																										
K	2008	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2008	Tahoe Hybrid	Body	Radio																																																										
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																										
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Avalanche	Chassis	Electronic Brake Control Module			V																																																							
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																															
K	2009	Avalanche	Body	Amplifier (Bose)																																																															
K	2009	Avalanche	Body	Assist Step Controller																																																															
K	2009	Avalanche	Body	Body Control Module															V	V	V	V	V	V	V																																									
K	2009	Avalanche	Body	Body Control Module (aux.)																																																															
K	2009	Avalanche	Body	Digital Radio Receiver																																																															
K	2009	Avalanche	Body	Driver Door Switch																																																															
K	2009	Avalanche	Body	HVAC Control Module Auto																																																															
K	2009	Avalanche	Body	HVAC Control Module Manual																																																															
K	2009	Avalanche	Body	Instrument Panel Cluster																																																															
K	2009	Avalanche	Body	Memory Seat Module																																																															
K	2009	Avalanche	Body	Park Assist Module																																																															
K	2009	Avalanche	Body	Passenger Door Switch																																																															
K	2009	Avalanche	Body	Passenger Presence System																																																															
K	2009	Avalanche	Body	Radio																																																															
K	2009	Avalanche	Body	Rear Heated Seat Module																																																															
K	2009	Avalanche	Body	Rear HVAC/RSA																																																															
K	2009	Avalanche	Body	Rollover Sensor																																																															
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																															
K	2009	Avalanche	Body	Theft Deterrent Module																																																															
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																					
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																															
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																															
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																					
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																															
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																															
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES			V																																																												
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																															
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																															
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																															
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																															
K	2009	Cheyenne	Body	Amplifier (Bose)																																																															
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																															
K	2009	Cheyenne	Body	Digital Radio Receiver																																																															
K	2009	Cheyenne	Body	Driver Door Switch																																																															
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																															
K	2009	Cheyenne	Body	Park Assist Module																																																															
K	2009	Cheyenne	Body	Passenger Door Switch																																																															
K	2009	Cheyenne	Body	Passenger Presence System																																																															
K	2009	Cheyenne	Body	Rear Heated Seat Module																																																															
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																															
K	2009	Cheyenne	Body	Rollover Sensor																																																															
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																															
K	2009	Cheyenne	Body	Theft Deterrent Module																																																															
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																					
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																															
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																			
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																			
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module										V																																																			
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																													
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																			
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																													
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																			
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2009	Suburban	Chassis	EBCM Under 8600 GVW			V																																																										
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2009	Suburban	Chassis	Electronic Suspension Control																																																													
K	2009	Suburban	Chassis	Trailer Brake Control Module																																																													
K	2009	Suburban	Body	Amplifier (Bose)																																																													
K	2009	Suburban	Body	Assist Step Controller																																																													
K	2009	Suburban	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2009	Suburban	Body	Body Control Module (aux.)																																																													
K	2009	Suburban	Body	Digital Radio Receiver																																																													
K	2009	Suburban	Body	Driver Door Switch																																																													
K	2009	Suburban	Body	HVAC Control Module Auto																																																													
K	2009	Suburban	Body	HVAC Control Module Manual																																																													
K	2009	Suburban	Body	Instrument Panel Cluster																																																													
K	2009	Suburban	Body	Left Side Object Detection Module						V																																																						
K	2009	Suburban	Body	Lift Gate Module																									V	V																																			
K	2009	Suburban	Body	Memory Seat Module																																																													
K	2009	Suburban	Body	Park Assist Module																																																													
K	2009	Suburban	Body	Passenger Door Switch																																																													
K	2009	Suburban	Body	Passenger Presence System																																																													
K	2009	Suburban	Body	Radio																																																													
K	2009	Suburban	Body	Rear Heated Seat Module																																																													
K	2009	Suburban	Body	Rear HVAC/RSA																																																													
K	2009	Suburban	Body	Right Side Object Detection Module						V																																																						
K	2009	Suburban	Body	Rollover Sensor																																																													
K	2009	Suburban	Body	Supplemental Inflatable Restraint																																																													
K	2009	Suburban	Body	Theft Deterrent Module																																																													
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module										V																																																			
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																													
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																			
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																													
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																													
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																			

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																		
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																		
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																		
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																		
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																												
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																		
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES			V																																																									
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2009	Silverado	Chassis	Electronic Suspension Control																																																												
K	2009	Silverado	Chassis	Trailer Brake Control Module																																																												
K	2009	Silverado	Body	Amplifier (Bose)																																																												
K	2009	Silverado	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2009	Silverado	Body	Body Control Module (aux.)																																																												
K	2009	Silverado	Body	Digital Radio Receiver																																																												
K	2009	Silverado	Body	Driver Door Switch																																																												
K	2009	Silverado	Body	HVAC Control Module Auto																																																												
K	2009	Silverado	Body	HVAC Control Module Manual																																																												
K	2009	Silverado	Body	Instrument Panel Cluster																																																												
K	2009	Silverado	Body	Memory Seat Module																																																												
K	2009	Silverado	Body	Park Assist Module																																																												
K	2009	Silverado	Body	Passenger Door Switch																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2009	Silverado	Body	Passenger Presence System																																																												
K	2009	Silverado	Body	Radio																																																												
K	2009	Silverado	Body	Rear Heated Seat Module																																																												
K	2009	Silverado	Body	Rear HVAC/RSA																																																												
K	2009	Silverado	Body	Rollover Sensor																																																												
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2009	Silverado	Body	Theft Deterrent Module																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2009	Silverado Hybrid	Body	Body Control Module														V	V	V	V	V	V	V																																								
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2009	Silverado Hybrid	Body	HVAC Control Module																																																												
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2009	Silverado Hybrid	Body	Memory Seat Module																																																												
K	2009	Silverado Hybrid	Body	Park Assist Module																																																												
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2009	Silverado Hybrid	Body	Passenger Presence System																																																												
K	2009	Silverado Hybrid	Body	Radio																																																												
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																												
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																												
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																		
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																		
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																		
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																			
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																													
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																													
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																			
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																													
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2009	Tahoe	Chassis	Electronic Brake Control Module			V																																																										
K	2009	Tahoe	Chassis	Electronic Suspension Control																																																													
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																																													
K	2009	Tahoe	Body	Amplifier (Bose)																																																													
K	2009	Tahoe	Body	Assist Step Controller																																																													
K	2009	Tahoe	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2009	Tahoe	Body	Body Control Module (aux.)																																																													
K	2009	Tahoe	Body	Digital Radio Receiver																																																													
K	2009	Tahoe	Body	Driver Door Switch																																																													
K	2009	Tahoe	Body	HVAC Control Module Auto																																																													
K	2009	Tahoe	Body	HVAC Control Module Manual																																																													
K	2009	Tahoe	Body	Instrument Panel Cluster																																																													
K	2009	Tahoe	Body	Left Side Object Detection Module						V																																																						
K	2009	Tahoe	Body	Lift Gate Module																									V	V																																			
K	2009	Tahoe	Body	Memory Seat Module																																																													
K	2009	Tahoe	Body	Park Assist Module																																																													
K	2009	Tahoe	Body	Passenger Door Switch																																																													
K	2009	Tahoe	Body	Passenger Presence System																																																													
K	2009	Tahoe	Body	Radio																																																													
K	2009	Tahoe	Body	Rear Heated Seat Module																																																													
K	2009	Tahoe	Body	Rear HVAC/RSA																																																													
K	2009	Tahoe	Body	Right Side Object Detection Module						V																																																						
K	2009	Tahoe	Body	Rollover Sensor																																																													
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																													
K	2009	Tahoe	Body	Theft Deterrent Module																																																													
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																													
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																													
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																													
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																													
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																													
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																													
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																													
K	2009	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																							

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																																												
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																																												
K	2009	Tahoe Hybrid	Body	HVAC Control Module																																																												
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module						V																																																						
K	2009	Tahoe Hybrid	Body	Park Assist Module																																																												
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																												
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																																												
K	2009	Tahoe Hybrid	Body	Radio																																																												
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module						V																																																						
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																												
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Avalanche	Chassis	Electronic Brake Control Module			V																																																									
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																												
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Avalanche	Body	Amplifier (Bose)																																																												
K	2010	Avalanche	Body	Assist Step Controller																																																												
K	2010	Avalanche	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2010	Avalanche	Body	Body Control Module (aux.)																																																												
K	2010	Avalanche	Body	Digital Radio Receiver																																																												
K	2010	Avalanche	Body	Driver Door Switch																																																												
K	2010	Avalanche	Body	HVAC Control Module Auto																																																												
K	2010	Avalanche	Body	HVAC Control Module Manual																																																												
K	2010	Avalanche	Body	Instrument Panel Cluster																																																												
K	2010	Avalanche	Body	Memory Seat Module																																																												
K	2010	Avalanche	Body	Park Assist Module																																																												
K	2010	Avalanche	Body	Passenger Door Switch																																																												
K	2010	Avalanche	Body	Passenger Presence System																																																												
K	2010	Avalanche	Body	Radio																																																												
K	2010	Avalanche	Body	Rear Heated Seat Module																																																												
K	2010	Avalanche	Body	Rear HVAC/RSA																																																												
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
K	2010	Avalanche	Body	Theft Deterrent Module																																																												
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES			V																																																							
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Cheyenne	Body	Amplifier (Bose)																																																										
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2010	Cheyenne	Body	Digital Radio Receiver																																																										
K	2010	Cheyenne	Body	Driver Door Switch																																																										
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2010	Cheyenne	Body	Park Assist Module																																																										
K	2010	Cheyenne	Body	Passenger Door Switch																																																										
K	2010	Cheyenne	Body	Passenger Presence System																																																										
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
K	2010	Cheyenne	Body	Theft Deterrent Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Suburban	Chassis	EBCM Under 8600 GVW			V																																																							
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2010	Suburban	Chassis	Electronic Suspension Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Body	Amplifier (Bose)																																																										
K	2010	Suburban	Body	Assist Step Controller																																																										
K	2010	Suburban	Body	Body Control Module														V	V	V	V	V	V	V																																						
K	2010	Suburban	Body	Body Control Module (aux.)																																																										
K	2010	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2010	Suburban	Body	Driver Door Switch																																																											
K	2010	Suburban	Body	HVAC Control Module Auto																																																											
K	2010	Suburban	Body	HVAC Control Module Manual																																																											
K	2010	Suburban	Body	Instrument Panel Cluster																																																											
K	2010	Suburban	Body	Left Side Object Detection Module						V																																																					
K	2010	Suburban	Body	Lift Gate Module																								V	V			V	V																															
K	2010	Suburban	Body	Memory Seat Module																																																											
K	2010	Suburban	Body	Park Assist Module																																																											
K	2010	Suburban	Body	Passenger Door Switch																																																											
K	2010	Suburban	Body	Passenger Presence System																																																											
K	2010	Suburban	Body	Radio																																																											
K	2010	Suburban	Body	Rear Heated Seat Module																																																											
K	2010	Suburban	Body	Rear HVAC/RSA																																																											
K	2010	Suburban	Body	Right Side Object Detection Module						V																																																					
K	2010	Suburban	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
K	2010	Suburban	Body	Theft Deterrent Module																																																											
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																											
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																											
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES			V																																																								
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2010	Silverado	Chassis	Electronic Suspension Control																																																												
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2010	Silverado	Body	Amplifier (Bose)																																																												
K	2010	Silverado	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2010	Silverado	Body	Body Control Module (aux.)																																																												
K	2010	Silverado	Body	Digital Radio Receiver																																																												
K	2010	Silverado	Body	Driver Door Switch																																																												
K	2010	Silverado	Body	HVAC Control Module Auto																																																												
K	2010	Silverado	Body	HVAC Control Module Manual																																																												
K	2010	Silverado	Body	Instrument Panel Cluster																																																												
K	2010	Silverado	Body	Memory Seat Module																																																												
K	2010	Silverado	Body	Park Assist Module																																																												
K	2010	Silverado	Body	Passenger Door Switch																																																												
K	2010	Silverado	Body	Passenger Presence System																																																												
K	2010	Silverado	Body	Radio																																																												
K	2010	Silverado	Body	Rear Heated Seat Module																																																												
K	2010	Silverado	Body	Rear HVAC/RSA																																																												
K	2010	Silverado	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
K	2010	Silverado	Body	Theft Deterrent Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2010	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2010	Silverado Hybrid	Body	Heated Seat Module																																																												
K	2010	Silverado Hybrid	Body	HVAC Control Module																																																												
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2010	Silverado Hybrid	Body	Park Assist Module																																																												
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2010	Silverado Hybrid	Body	Passenger Presence System																																																												
K	2010	Silverado Hybrid	Body	Radio																																																												
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																									

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Tahoe	Chassis	Electronic Brake Control Module			V																																																							
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Tahoe	Body	Amplifier (Bose)																																																										
K	2010	Tahoe	Body	Assist Step Controller																																																										
K	2010	Tahoe	Body	Body Control Module															V	V	V	V	V	V	V																																					
K	2010	Tahoe	Body	Body Control Module (aux.)																																																										
K	2010	Tahoe	Body	Digital Radio Receiver																																																										
K	2010	Tahoe	Body	Driver Door Switch																																																										
K	2010	Tahoe	Body	HVAC Control Module Auto																																																										
K	2010	Tahoe	Body	HVAC Control Module Manual																																																										
K	2010	Tahoe	Body	Instrument Panel Cluster																																																										
K	2010	Tahoe	Body	Left Side Object Detection Module						V																																																				
K	2010	Tahoe	Body	Lift Gate Module																									V	V			V	V																												
K	2010	Tahoe	Body	Memory Seat Module																																																										
K	2010	Tahoe	Body	Park Assist Module																																																										
K	2010	Tahoe	Body	Passenger Door Switch																																																										
K	2010	Tahoe	Body	Passenger Presence System																																																										
K	2010	Tahoe	Body	Radio																																																										
K	2010	Tahoe	Body	Rear Heated Seat Module																																																										
K	2010	Tahoe	Body	Rear HVAC/RSA																																																										
K	2010	Tahoe	Body	Right Side Object Detection Module						V																																																				
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
K	2010	Tahoe	Body	Theft Deterrent Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																					

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2010	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module						V																																																				
K	2010	Tahoe Hybrid	Body	Lift Gate Module																									V	V			V	V																												
K	2010	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2010	Tahoe Hybrid	Body	Radio																																																										
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module						V																																																				
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																V	V	V	V																							
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2011	Avalanche	Chassis	Electronic Brake Control Module			V																																																							
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Avalanche	Body	Amplifier (Bose)																																																										
K	2011	Avalanche	Body	Assist Step Controller																																																										
K	2011	Avalanche	Body	Body Control Module															V	V	V	V	V	V	V																																					
K	2011	Avalanche	Body	Body Control Module (aux.)																																																										
K	2011	Avalanche	Body	Digital Radio Receiver																																																										
K	2011	Avalanche	Body	Driver Door Switch																																																										
K	2011	Avalanche	Body	HVAC Control Module Auto																																																										
K	2011	Avalanche	Body	HVAC Control Module Manual																																																										
K	2011	Avalanche	Body	Instrument Panel Cluster																																																										
K	2011	Avalanche	Body	Memory Seat Module																																																										
K	2011	Avalanche	Body	Park Assist Module																																																										
K	2011	Avalanche	Body	Passenger Door Switch																																																										
K	2011	Avalanche	Body	Passenger Presence System																																																										
K	2011	Avalanche	Body	Radio																																																										
K	2011	Avalanche	Body	Rear Heated Seat Module																																																										
K	2011	Avalanche	Body	Rear HVAC/RSA																																																										
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																V	V	V	V																							
K	2011	Avalanche	Body	Theft Deterrent Module																																																										
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES			V																																																									
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																												
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																												
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Cheyenne	Body	Amplifier (Bose)																																																												
K	2011	Cheyenne	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																												
K	2011	Cheyenne	Body	Digital Radio Receiver																																																												
K	2011	Cheyenne	Body	Driver Door Switch																																																												
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																												
K	2011	Cheyenne	Body	Park Assist Module																																																												
K	2011	Cheyenne	Body	Passenger Door Switch																																																												
K	2011	Cheyenne	Body	Passenger Presence System																																																												
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																												
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																												
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
K	2011	Cheyenne	Body	Theft Deterrent Module																																																												
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2011	Suburban	Chassis	EBCM Under 8600 GVW			V																																																									
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2011	Suburban	Chassis	Electronic Suspension Control																																																												
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Suburban	Body	Amplifier (Bose)																																																												
K	2011	Suburban	Body	Assist Step Controller																																																												
K	2011	Suburban	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2011	Suburban	Body	Body Control Module (aux.)																																																												
K	2011	Suburban	Body	Digital Radio Receiver																																																												
K	2011	Suburban	Body	Driver Door Switch																																																												
K	2011	Suburban	Body	HVAC Control Module Auto																																																												
K	2011	Suburban	Body	HVAC Control Module Manual																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2011	Suburban	Body	Instrument Panel Cluster																																																													
K	2011	Suburban	Body	Left Side Object Detection Module						V																																																							
K	2011	Suburban	Body	Lift Gate Module																								V	V			V	V																																
K	2011	Suburban	Body	Memory Seat Module																																																												
K	2011	Suburban	Body	Park Assist Module																																																												
K	2011	Suburban	Body	Passenger Door Switch																																																												
K	2011	Suburban	Body	Passenger Presence System																																																												
K	2011	Suburban	Body	Radio																																																											
K	2011	Suburban	Body	Rear Heated Seat Module																																																												
K	2011	Suburban	Body	Rear HVAC/RSA																																																												
K	2011	Suburban	Body	Right Side Object Detection Module						V																																																						
K	2011	Suburban	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
K	2011	Suburban	Body	Theft Deterrent Module																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic										V																																																	
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module										V																																																	
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																	
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES			V																																																									
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2011	Silverado	Chassis	Electronic Suspension Control																																																											
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
K	2011	Silverado	Body	Amplifier (Bose)																																																											
K	2011	Silverado	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2011	Silverado	Body	Body Control Module (aux.)																																																											
K	2011	Silverado	Body	Digital Radio Receiver																																																											
K	2011	Silverado	Body	Driver Door Switch																																																											
K	2011	Silverado	Body	HVAC Control Module Auto																																																											
K	2011	Silverado	Body	HVAC Control Module Manual																																																											
K	2011	Silverado	Body	Instrument Panel Cluster																																																											
K	2011	Silverado	Body	Memory Seat Module																																																											
K	2011	Silverado	Body	Park Assist Module																																																											
K	2011	Silverado	Body	Passenger Door Switch																																																											
K	2011	Silverado	Body	Passenger Presence System																																																											
K	2011	Silverado	Body	Radio																																																											
K	2011	Silverado	Body	Rear Heated Seat Module																																																											
K	2011	Silverado	Body	Rear HVAC/RSA																																																											
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																V	V	V	V																								
K	2011	Silverado	Body	Theft Deterrent Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																											
K	2011	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																											
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																											
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																											
K	2011	Silverado Hybrid	Body	HVAC Control Module																																																											
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
K	2011	Silverado Hybrid	Body	Park Assist Module																																																											
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																											
K	2011	Silverado Hybrid	Body	Passenger Presence System																																																											
K	2011	Silverado Hybrid	Body	Radio																																																											
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																V	V	V	V																								

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2011	Tahoe	Chassis	Electronic Brake Control Module			V																																																									
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Tahoe	Body	Amplifier (Bose)																																																												
K	2011	Tahoe	Body	Assist Step Controller																																																												
K	2011	Tahoe	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2011	Tahoe	Body	Body Control Module (aux.)																																																												
K	2011	Tahoe	Body	Digital Radio Receiver																																																												
K	2011	Tahoe	Body	Driver Door Switch																																																												
K	2011	Tahoe	Body	HVAC Control Module Auto																																																												
K	2011	Tahoe	Body	HVAC Control Module Manual																																																												
K	2011	Tahoe	Body	Instrument Panel Cluster																																																												
K	2011	Tahoe	Body	Left Side Object Detection Module						V																																																						
K	2011	Tahoe	Body	Lift Gate Module																									V	V			V	V																														
K	2011	Tahoe	Body	Memory Seat Module																																																												
K	2011	Tahoe	Body	Park Assist Module																																																												
K	2011	Tahoe	Body	Passenger Door Switch																																																												
K	2011	Tahoe	Body	Passenger Presence System																																																												
K	2011	Tahoe	Body	Radio																																																												
K	2011	Tahoe	Body	Rear Heated Seat Module																																																												
K	2011	Tahoe	Body	Rear HVAC/RSA																																																												
K	2011	Tahoe	Body	Right Side Object Detection Module						V																																																						
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
K	2011	Tahoe	Body	Theft Deterrent Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
K	2011	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																																												
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																																												
K	2011	Tahoe Hybrid	Body	HVAC Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module						V																																																					
K	2011	Tahoe Hybrid	Body	Lift Gate Module																								V	V			V	V																														
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																											
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																																											
K	2011	Tahoe Hybrid	Body	Radio																																																											
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module						V																																																					
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2012	Avalanche	Chassis	Electronic Brake Control Module			V																																																								
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Avalanche	Body	Amplifier (Bose)																																																											
K	2012	Avalanche	Body	Assist Step Controller																																																											
K	2012	Avalanche	Body	Body Control Module														V	V	V	V	V	V	V																																							
K	2012	Avalanche	Body	Body Control Module (aux.)																																																											
K	2012	Avalanche	Body	Digital Radio Receiver																																																											
K	2012	Avalanche	Body	Driver Door Switch																																																											
K	2012	Avalanche	Body	HVAC Control Module Auto																																																											
K	2012	Avalanche	Body	HVAC Control Module Manual																																																											
K	2012	Avalanche	Body	Instrument Panel Cluster																																																											
K	2012	Avalanche	Body	Memory Seat Module																																																											
K	2012	Avalanche	Body	Navigation Radio																																																											
K	2012	Avalanche	Body	Park Assist Module																																																											
K	2012	Avalanche	Body	Passenger Door Switch																																																											
K	2012	Avalanche	Body	Passenger Presence System																																																											
K	2012	Avalanche	Body	Radio																																																											
K	2012	Avalanche	Body	Rear Heated Seat Module																																																											
K	2012	Avalanche	Body	Rear HVAC/RSA																																																											
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
K	2012	Avalanche	Body	Theft Deterrent Module																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES			V																																																								
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																											
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Cheyenne	Body	Amplifier (Bose)																																																											
K	2012	Cheyenne	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2012	Cheyenne	Body	Digital Radio Receiver																																																											
K	2012	Cheyenne	Body	Driver Door Switch																																																											
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2012	Cheyenne	Body	Park Assist Module																																																											
K	2012	Cheyenne	Body	Passenger Door Switch																																																											
K	2012	Cheyenne	Body	Passenger Presence System																																																											
K	2012	Cheyenne	Body	Rear Heated Seat Module																																																											
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
K	2012	Cheyenne	Body	Theft Deterrent Module																																																											
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2012	Suburban	Chassis	EBCM Under 8600 GVW			V																																																								
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2012	Suburban	Chassis	Electronic Suspension Control																																																											
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Suburban	Body	Amplifier (Bose)																																																											
K	2012	Suburban	Body	Assist Step Controller																																																											
K	2012	Suburban	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2012	Suburban	Body	Body Control Module (aux.)																																																											
K	2012	Suburban	Body	Digital Radio Receiver																																																											
K	2012	Suburban	Body	Driver Door Switch																																																											
K	2012	Suburban	Body	HVAC Control Module Auto																																																											
K	2012	Suburban	Body	HVAC Control Module Manual																																																											
K	2012	Suburban	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2012	Suburban	Body	Left Side Object Detection Module						V																																																					
K	2012	Suburban	Body	Lift Gate Module																								V	V			V	V																													
K	2012	Suburban	Body	Memory Seat Module																																																										
K	2012	Suburban	Body	Navigation Radio																																																										
K	2012	Suburban	Body	Park Assist Module																																																										
K	2012	Suburban	Body	Passenger Door Switch																																																										
K	2012	Suburban	Body	Passenger Presence System																																																										
K	2012	Suburban	Body	Radio																																																										
K	2012	Suburban	Body	Rear Heated Seat Module																																																										
K	2012	Suburban	Body	Rear HVAC/RSA																																																										
K	2012	Suburban	Body	Right Side Object Detection Module						V																																																				
K	2012	Suburban	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
K	2012	Suburban	Body	Theft Deterrent Module																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic										V																																															
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module										V																																															
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																															
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES			V																																																							
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2012	Silverado	Chassis	Electronic Suspension Control																																																											
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
K	2012	Silverado	Body	Amplifier (Bose)																																																											
K	2012	Silverado	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2012	Silverado	Body	Body Control Module (aux.)																																																											
K	2012	Silverado	Body	Digital Radio Receiver																																																											
K	2012	Silverado	Body	Driver Door Switch																																																											
K	2012	Silverado	Body	HVAC Control Module Auto																																																											
K	2012	Silverado	Body	HVAC Control Module Manual																																																											
K	2012	Silverado	Body	Instrument Panel Cluster																																																											
K	2012	Silverado	Body	Memory Seat Module																																																											
K	2012	Silverado	Body	Navigation Radio																																																											
K	2012	Silverado	Body	Park Assist Module																																																											
K	2012	Silverado	Body	Passenger Door Switch																																																											
K	2012	Silverado	Body	Passenger Presence System																																																											
K	2012	Silverado	Body	Radio																																																											
K	2012	Silverado	Body	Rear Heated Seat Module																																																											
K	2012	Silverado	Body	Rear HVAC/RSA																																																											
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																V	V	V	V																								
K	2012	Silverado	Body	Theft Deterrent Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																											
K	2012	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																											
K	2012	Silverado Hybrid	Body	Driver Door Switch																																																											
K	2012	Silverado Hybrid	Body	Heated Seat Module																																																											
K	2012	Silverado Hybrid	Body	HVAC Control Module																																																											
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
K	2012	Silverado Hybrid	Body	Navigation Radio																																																											
K	2012	Silverado Hybrid	Body	Park Assist Module																																																											
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																																											
K	2012	Silverado Hybrid	Body	Passenger Presence System																																																											
K	2012	Silverado Hybrid	Body	Radio																																																											
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																V	V	V	V																								

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2012	Tahoe	Chassis	EBCM with Trailer Brake			V																																																							
K	2012	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Tahoe	Body	Amplifier (Bose)																																																										
K	2012	Tahoe	Body	Assist Step Controller																																																										
K	2012	Tahoe	Body	Body Control Module														V	V	V	V	V	V	V																																						
K	2012	Tahoe	Body	Body Control Module (aux.)																																																										
K	2012	Tahoe	Body	Digital Radio Receiver																																																										
K	2012	Tahoe	Body	Driver Door Switch																																																										
K	2012	Tahoe	Body	HVAC Control Module Auto																																																										
K	2012	Tahoe	Body	HVAC Control Module Manual																																																										
K	2012	Tahoe	Body	Instrument Panel Cluster																																																										
K	2012	Tahoe	Body	Left Side Object Detection Module						V																																																				
K	2012	Tahoe	Body	Lift Gate Module																									V	V			V	V																												
K	2012	Tahoe	Body	Memory Seat Module																																																										
K	2012	Tahoe	Body	Navigation Radio																																																										
K	2012	Tahoe	Body	Park Assist Module																																																										
K	2012	Tahoe	Body	Passenger Door Switch																																																										
K	2012	Tahoe	Body	Passenger Presence System																																																										
K	2012	Tahoe	Body	Radio																																																										
K	2012	Tahoe	Body	Rear Heated Seat Module																																																										
K	2012	Tahoe	Body	Rear HVAC/RSA																																																										
K	2012	Tahoe	Body	Right Side Object Detection Module						V																																																				
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
K	2012	Tahoe	Body	Theft Deterrent Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2012	Tahoe Hybrid	Body	Body Control Module														V	V	V	V	V	V	V																																						
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2012	Tahoe Hybrid	Body	HVAC Control Module																																																											
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module						V																																																			
K	2012	Tahoe Hybrid	Body	Lift Gate Module																								V	V			V	V																												
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																									
K	2012	Tahoe Hybrid	Body	Park Assist Module																																																									
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																									
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																																									
K	2012	Tahoe Hybrid	Body	Radio																																																									
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																									
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module						V																																																			
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																						
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																									
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2013	Avalanche	Chassis	Electronic Brake Control Module			V																																																						
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																									
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Avalanche	Body	Amplifier (Bose)																																																									
K	2013	Avalanche	Body	Assist Step Controller																																																									
K	2013	Avalanche	Body	Body Control Module															V	V	V	V	V	V	V																																			
K	2013	Avalanche	Body	Body Control Module (aux.)																																																									
K	2013	Avalanche	Body	Digital Radio Receiver																																																									
K	2013	Avalanche	Body	Driver Door Switch																																																									
K	2013	Avalanche	Body	HVAC Control Module Auto																																																									
K	2013	Avalanche	Body	HVAC Control Module Manual																																																									
K	2013	Avalanche	Body	Instrument Panel Cluster																																																									
K	2013	Avalanche	Body	Memory Seat Module																																																									
K	2013	Avalanche	Body	Navigation Radio																																																									
K	2013	Avalanche	Body	Park Assist Module																																																									
K	2013	Avalanche	Body	Passenger Door Switch																																																									
K	2013	Avalanche	Body	Passenger Presence System																																																									
K	2013	Avalanche	Body	Radio																																																									
K	2013	Avalanche	Body	Rear Heated Seat Module																																																									
K	2013	Avalanche	Body	Rear HVAC/RSA																																																									
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																															V	V	V	V																						
K	2013	Avalanche	Body	Theft Deterrent Module																																																									
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																									
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																									
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES			V																																																									
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																												
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Cheyenne	Body	Amplifier (Bose)																																																												
K	2013	Cheyenne	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																												
K	2013	Cheyenne	Body	Digital Radio Receiver																																																												
K	2013	Cheyenne	Body	Driver Door Switch																																																												
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																												
K	2013	Cheyenne	Body	Park Assist Module																																																												
K	2013	Cheyenne	Body	Passenger Door Switch																																																												
K	2013	Cheyenne	Body	Passenger Presence System																																																												
K	2013	Cheyenne	Body	Rear Heated Seat Module																																																												
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																												
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
K	2013	Cheyenne	Body	Theft Deterrent Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																												
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2013	Suburban	Chassis	EBCM Under 8600 GVW			V																																																									
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2013	Suburban	Chassis	Electronic Suspension Control																																																												
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Suburban	Body	Amplifier (Bose)																																																												
K	2013	Suburban	Body	Assist Step Controller																																																												
K	2013	Suburban	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2013	Suburban	Body	Body Control Module (aux.)																																																												
K	2013	Suburban	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2013	Suburban	Body	Driver Door Switch																																																											
K	2013	Suburban	Body	HVAC Control Module Auto																																																											
K	2013	Suburban	Body	HVAC Control Module Manual																																																											
K	2013	Suburban	Body	Instrument Panel Cluster																																																											
K	2013	Suburban	Body	Left Side Object Detection Module						V																																																					
K	2013	Suburban	Body	Lift Gate Module																								V	V			V	V																															
K	2013	Suburban	Body	Memory Seat Module																																																											
K	2013	Suburban	Body	Navigation Radio																																																											
K	2013	Suburban	Body	Park Assist Module																																																											
K	2013	Suburban	Body	Passenger Door Switch																																																											
K	2013	Suburban	Body	Passenger Presence System																																																											
K	2013	Suburban	Body	Radio																																																											
K	2013	Suburban	Body	Rear Heated Seat Module																																																											
K	2013	Suburban	Body	Rear HVAC/RSA																																																											
K	2013	Suburban	Body	Right Side Object Detection Module						V																																																					
K	2013	Suburban	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
K	2013	Suburban	Body	Theft Deterrent Module																																																											
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic										V																																																
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																											
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																											
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																											
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module										V																																																
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																											
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES			V																																																								

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																													
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													
K	2013	Silverado	Chassis	Electronic Suspension Control																																																													
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																													
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																													
K	2013	Silverado	Body	Amplifier (Bose)																																																													
K	2013	Silverado	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2013	Silverado	Body	Body Control Module (aux.)																																																													
K	2013	Silverado	Body	Digital Radio Receiver																																																													
K	2013	Silverado	Body	Driver Door Switch																																																													
K	2013	Silverado	Body	HVAC Control Module Auto																																																													
K	2013	Silverado	Body	HVAC Control Module Manual																																																													
K	2013	Silverado	Body	Instrument Panel Cluster																																																													
K	2013	Silverado	Body	Memory Seat Module																																																													
K	2013	Silverado	Body	Navigation Radio																																																													
K	2013	Silverado	Body	Park Assist Module																																																													
K	2013	Silverado	Body	Passenger Door Switch																																																													
K	2013	Silverado	Body	Passenger Presence System																																																													
K	2013	Silverado	Body	Radio																																																													
K	2013	Silverado	Body	Rear Heated Seat Module																																																													
K	2013	Silverado	Body	Rear HVAC/RSA																																																													
K	2013	Silverado	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
K	2013	Silverado	Body	Theft Deterrent Module																																																													
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																														
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																													
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																													
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																													
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																													
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																													
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																													
K	2013	Silverado Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																													
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																													
K	2013	Silverado Hybrid	Body	Driver Door Switch																																																													
K	2013	Silverado Hybrid	Body	Heated Seat Module																																																													
K	2013	Silverado Hybrid	Body	HVAC Control Module																																																													
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																													
K	2013	Silverado Hybrid	Body	Navigation Radio																																																													
K	2013	Silverado Hybrid	Body	Park Assist Module																																																													
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																																													
K	2013	Silverado Hybrid	Body	Passenger Presence System																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2013	Silverado Hybrid	Body	Radio																																																										
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																V	V	V	V																							
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Tahoe	Chassis	Electronic Brake Control Module			V																																																							
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe	Body	Amplifier (Bose)																																																										
K	2013	Tahoe	Body	Assist Step Controller																																																										
K	2013	Tahoe	Body	Body Control Module															V	V	V	V	V	V	V																																					
K	2013	Tahoe	Body	Body Control Module (aux.)																																																										
K	2013	Tahoe	Body	Digital Radio Receiver																																																										
K	2013	Tahoe	Body	Driver Door Switch																																																										
K	2013	Tahoe	Body	HVAC Control Module Auto																																																										
K	2013	Tahoe	Body	HVAC Control Module Manual																																																										
K	2013	Tahoe	Body	Instrument Panel Cluster																																																										
K	2013	Tahoe	Body	Left Side Object Detection Module						V																																																				
K	2013	Tahoe	Body	Lift Gate Module																									V	V			V	V																												
K	2013	Tahoe	Body	Memory Seat Module																																																										
K	2013	Tahoe	Body	Navigation Radio																																																										
K	2013	Tahoe	Body	Park Assist Module																																																										
K	2013	Tahoe	Body	Passenger Door Switch																																																										
K	2013	Tahoe	Body	Passenger Presence System																																																										
K	2013	Tahoe	Body	Radio																																																										
K	2013	Tahoe	Body	Rear Heated Seat Module																																																										
K	2013	Tahoe	Body	Rear HVAC/RSA																																																										
K	2013	Tahoe	Body	Right Side Object Detection Module						V																																																				
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																V	V	V	V																							
K	2013	Tahoe	Body	Theft Deterrent Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																														
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																														
K	2013	Tahoe Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																									
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																														
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																														
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																													
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																													
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																																													
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																													
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module						V																																																						
K	2013	Tahoe Hybrid	Body	Lift Gate Module																								V	V			V	V																																
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																													
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																													
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																													
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																																													
K	2013	Tahoe Hybrid	Body	Radio																																																													
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																													
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																													
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module						V																																																						
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																													
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																													
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																														
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																														
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																														
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																														
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																														
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																														
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																														
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																														
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																														
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																														
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																														
K	2014	Cheyenne	Chassis	Power Steering Control Module																																																														
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																														
K	2014	Cheyenne	Body	Body Control Module																																																														
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
K	2014	Cheyenne	Body	Passenger Presence Module																																																														
K	2014	Cheyenne	Body	Instrument Cluster																																																														
K	2014	Cheyenne	Body	Radio Control																																																														
K	2014	Cheyenne	Body	HVAC Control																																																														
K	2014	Cheyenne	Body	Radio																																																														
K	2014	Cheyenne	Body	Amplifier																																																														
K	2014	Cheyenne	Body	Media Disc Player																																																														
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																														
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2014	Cheyenne	Body	HVAC Control Module																																																												
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																												
K	2014	Cheyenne	Body	Parking Assist Control Module																																																												
K	2014	Cheyenne	Body	Frontview Camera Module																																																												
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2014	Silverado	Chassis	Electronic Brake Control Module																																																												
K	2014	Silverado	Chassis	Parking Brake Control Module																																																												
K	2014	Silverado	Chassis	Power Steering Control Module																																																												
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2014	Silverado	Body	Body Control Module																																																												
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Silverado	Body	Passenger Presence Module																																																												
K	2014	Silverado	Body	Instrument Cluster																																																												
K	2014	Silverado	Body	Radio Control																																																											
K	2014	Silverado	Body	HVAC Control																																																											
K	2014	Silverado	Body	Radio																																																											
K	2014	Silverado	Body	Amplifier																																																											
K	2014	Silverado	Body	Media Disc Player																																																											
K	2014	Silverado	Body	Human Machine Interface Control Module																																																											
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																											
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
K	2014	Silverado	Body	Parking Assist Control Module																																																											
K	2014	Silverado	Body	Frontview Camera Module																																																											
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																											
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																											
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2014	Silverado HD	Chassis	Suspension Control Module																																																										
K	2014	Silverado HD	Body	Body Control Module																																						V	V	V	V	V	V	V	V	V	V											
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Silverado HD	Body	Passenger Presence Module																																																	V									
K	2014	Silverado HD	Body	Instrument Cluster																																																										
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
K	2014	Silverado HD	Body	Base Radio																																																										
K	2014	Silverado HD	Body	Navigation Radio																																																										
K	2014	Silverado HD	Body	Uplevel Radio																																																										
K	2014	Silverado HD	Body	Amplifier																																																										
K	2014	Silverado HD	Body	Rear Audio Control Module																																																										
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																										
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																										
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																	V									
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																	V									
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																	V									
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																	V									
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Silverado HD	Body	Seat Memory Control Module																																																								V	V	
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																										
K	2014	Silverado HD	Body	Parking Assist Control Module																																																										
K	2014	Silverado HD	Body	Theft Deterrent Module																																																										
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																										
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2014	Suburban	Chassis	Parking Brake Control Module																																																										
K	2014	Suburban	Chassis	Suspension Control Module																																																										
K	2014	Suburban	Body	Body Control Module																																						V	V	V	V	V	V	V	V	V	V											
K	2014	Suburban	Body	Auxiliary Body Control Module																																																										
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Suburban	Body	Passenger Presence Module																																																	V									
K	2014	Suburban	Body	Instrument Cluster																																																										
K	2014	Suburban	Body	Base Radio																																																										
K	2014	Suburban	Body	Navigation Radio																																																										
K	2014	Suburban	Body	Uplevel Radio																																																										
K	2014	Suburban	Body	Amplifier																																																										
K	2014	Suburban	Body	Rear Audio Control Module																																																										
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																										
K	2014	Suburban	Body	Personal Audio Link Control Module																																																										
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																	V								
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																	V								
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																									
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																									
K	2014	Suburban	Body	Liftgate Control Module																																																				V	V	V	V			
K	2014	Suburban	Body	Seat Memory Control Module																																																								V	V
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																									
K	2014	Suburban	Body	Assist Step Control Module																																																									
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																									
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																									
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																									
K	2014	Suburban	Body	Parking Assist Control Module																																																									
K	2014	Suburban	Body	Theft Deterrent Module																																																									
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																									
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																									
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																									
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																									
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																									
K	2014	Tahoe	Chassis	Suspension Control Module																																																									
K	2014	Tahoe	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V											
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																									
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2014	Tahoe	Body	Passenger Presence Module																																																	V								
K	2014	Tahoe	Body	Instrument Cluster																																																									
K	2014	Tahoe	Body	Base Radio																																																									
K	2014	Tahoe	Body	Navigation Radio																																																									
K	2014	Tahoe	Body	Uplevel Radio																																																									
K	2014	Tahoe	Body	Amplifier																																																									
K	2014	Tahoe	Body	Rear Audio Control Module																																																									
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																									
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																									
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																									
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																									
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																	V								
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																	V								
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																									
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																									
K	2014	Tahoe	Body	Liftgate Control Module																																																				V	V	V	V			
K	2014	Tahoe	Body	Seat Memory Control Module																																																								V	V
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																									
K	2014	Tahoe	Body	Assist Step Control Module																																																									
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																									
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																									
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																									
K	2014	Tahoe	Body	Parking Assist Control Module																																																									
K	2014	Tahoe	Body	Theft Deterrent Module																																																									
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																												
K	2015	Cheyenne	Chassis	Power Steering Control Module																																																												
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Cheyenne	Chassis	Suspension Control Module																																																												
K	2015	Cheyenne	Body	Body Control Module																																					V																							
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Cheyenne	Body	Passenger Presence Module																																																												
K	2015	Cheyenne	Body	Instrument Cluster																																																												
K	2015	Cheyenne	Body	Radio Controls																																																												
K	2015	Cheyenne	Body	HVAC Controls																																																												
K	2015	Cheyenne	Body	Radio																																																												
K	2015	Cheyenne	Body	Amplifier																																																												
K	2015	Cheyenne	Body	Media Disc Player																																																												
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																												
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																												
K	2015	Cheyenne	Body	HVAC Control Module																																																												
K	2015	Cheyenne	Body	Parking Assist Control Module																																																												
K	2015	Cheyenne	Body	Frontview Camera Module																																																												
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																													
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																													
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																													
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																													
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																													
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
K	2015	Silverado	Chassis	Electronic Brake Control Module																																																													
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																													
K	2015	Silverado	Chassis	Power Steering Control Module																																																													
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																													
K	2015	Silverado	Chassis	Suspension Control Module																																																													
K	2015	Silverado	Body	Body Control Module																																					V																									
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
K	2015	Silverado	Body	Passenger Presence Module																																																													
K	2015	Silverado	Body	Instrument Cluster																																																													
K	2015	Silverado	Body	Radio Controls																																																													
K	2015	Silverado	Body	HVAC Controls																																																													
K	2015	Silverado	Body	Radio																																																													
K	2015	Silverado	Body	Amplifier																																																													
K	2015	Silverado	Body	Media Disc Player																																																													
K	2015	Silverado	Body	Human Machine Interface Control Module																																																													
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																																													
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																													
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																													
K	2015	Silverado	Body	Parking Assist Control Module																																																													
K	2015	Silverado	Body	Frontview Camera Module																																																													
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																													
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																													
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																													
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																													
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																													
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
K	2015	Suburban	Chassis	Electronic Brake Control Module																																																													
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																													
K	2015	Suburban	Chassis	Parking Brake Control Module																																																													
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																													
K	2015	Suburban	Chassis	Power Steering Control Module																																																													
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																													
K	2015	Suburban	Chassis	Suspension Control Module																																																													
K	2015	Suburban	Body	Body Control Module																																																													
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
K	2015	Suburban	Body	Passenger Presence Module																																																													
K	2015	Suburban	Body	Instrument Cluster																																																													
K	2015	Suburban	Body	Radio Controls																																																													
K	2015	Suburban	Body	HVAC Controls																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2015	Suburban	Body	Radio																																																										
K	2015	Suburban	Body	Amplifier																																																										
K	2015	Suburban	Body	Media Disc Player																																																										
K	2015	Suburban	Body	Human Machine Interface Control Module																																																										
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																										
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																										
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2015	Suburban	Body	HVAC Control Module																																																										
K	2015	Suburban	Body	Liftgate Control Module																																																					V	V	V	V		
K	2015	Suburban	Body	Keyless Entry Control Module																																																										
K	2015	Suburban	Body	Assist Step Control Module																																																										
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																										
K	2015	Suburban	Body	Parking Assist Control Module																																																										
K	2015	Suburban	Body	Frontview Camera Module																																																										
K	2015	Suburban	Body	Steering Column Lock Control Module																																																										
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																										
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																										
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																										
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																										
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2015	Tahoe	Chassis	Power Steering Control Module																																																										
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Tahoe	Chassis	Suspension Control Module																																																										
K	2015	Tahoe	Body	Body Control Module																																																										
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Tahoe	Body	Passenger Presence Module																																																										
K	2015	Tahoe	Body	Instrument Cluster																																																										
K	2015	Tahoe	Body	Radio Controls																																																										
K	2015	Tahoe	Body	HVAC Controls																																																										
K	2015	Tahoe	Body	Radio																																																										
K	2015	Tahoe	Body	Amplifier																																																										
K	2015	Tahoe	Body	Media Disc Player																																																										
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																										
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																										
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																										
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2015	Tahoe	Body	HVAC Control Module																																																										
K	2015	Tahoe	Body	Liftgate Control Module																																																					V	V	V	V		
K	2015	Tahoe	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2015	Tahoe	Body	Assist Step Control Module																																																												
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																												
K	2015	Tahoe	Body	Parking Assist Control Module																																																												
K	2015	Tahoe	Body	Frontview Camera Module																																																												
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																												
K	2015	Tahoe	Body	Battery Energy Control Module																																																												
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																												
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																												
K	2016	Cheyenne	Chassis	Power Steering Control Module																																																												
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2016	Cheyenne	Chassis	Suspension Control Module																																																												
K	2016	Cheyenne	Body	Body Control Module																																																												
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2016	Cheyenne	Body	Passenger Presence Module																																																												
K	2016	Cheyenne	Body	Instrument Cluster																																																												
K	2016	Cheyenne	Body	Radio Controls																																																												
K	2016	Cheyenne	Body	HVAC Controls																																																												
K	2016	Cheyenne	Body	Radio																																																												
K	2016	Cheyenne	Body	Amplifier																																																												
K	2016	Cheyenne	Body	Media Disc Player																																																												
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																												
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																												
K	2016	Cheyenne	Body	HVAC Control Module																																																												
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																												
K	2016	Cheyenne	Body	Parking Assist Control Module																																																												
K	2016	Cheyenne	Body	Frontview Camera Module																																																												
K	2016	Cheyenne	Body	Frontview Camera Module																																																												
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																												
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																												
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																												
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																												
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																												
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																												
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																													
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																													
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																													
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																													
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																													
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																													
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																													
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																													
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
K	2016	Silverado	Chassis	Electronic Brake Control Module																																																													
K	2016	Silverado	Chassis	Power Steering Control Module																																																													
K	2016	Silverado	Chassis	Power Steering Control Module																																																													
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																													
K	2016	Silverado	Chassis	Suspension Control Module																																																													
K	2016	Silverado	Body	Body Control Module																																																													
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
K	2016	Silverado	Body	Passenger Presence Module																																																													
K	2016	Silverado	Body	Instrument Cluster																																																													
K	2016	Silverado	Body	Radio Controls																																																												
K	2016	Silverado	Body	HVAC Controls																																																												
K	2016	Silverado	Body	Radio (IO3)																																																												
K	2016	Silverado	Body	Radio (IOB)																																																												
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																												
K	2016	Silverado	Body	Amplifier																																																												
K	2016	Silverado	Body	Media Disc Player																																																												
K	2016	Silverado	Body	Human Machine Interface Control Module																																																												
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																												
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																												
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																												
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																												
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																												
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																												
K	2016	Silverado	Body	Parking Assist Control Module																																																												
K	2016	Silverado	Body	Frontview Camera Module																																																												
K	2016	Silverado	Body	Frontview Camera Module																																																												
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2016	Suburban	Chassis	Electronic Brake Control Module																																																												
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																												
K	2016	Suburban	Chassis	Parking Brake Control Module																																																												
K	2016	Suburban	Chassis	Power Steering Control Module																																																												
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2016	Suburban	Chassis	Suspension Control Module																																																												
K	2016	Suburban	Body	Body Control Module																																																												
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2016	Suburban	Body	Passenger Presence Module																																																												
K	2016	Suburban	Body	Instrument Cluster																																																												
K	2016	Suburban	Body	Radio Controls																																																												
K	2016	Suburban	Body	HVAC Controls																																																												
K	2016	Suburban	Body	Radio																																																												
K	2016	Suburban	Body	Amplifier																																																												
K	2016	Suburban	Body	Media Disc Player																																																												
K	2016	Suburban	Body	Human Machine Interface Control Module																																																												
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																																												
K	2016	Suburban	Body	HVAC Control Module																																																												
K	2016	Suburban	Body	Liftgate Control Module																																																						V	V	V	V			
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																												
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																												
K	2016	Suburban	Body	Keyless Entry Control Module																																																												
K	2016	Suburban	Body	Assist Step Control Module																																																												
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																												
K	2016	Suburban	Body	Parking Assist Control Module																																																												
K	2016	Suburban	Body	Frontview Camera Module																																																												
K	2016	Suburban	Body	Steering Column Lock Control Module																																																												
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																												
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																												
K	2016	Tahoe	Chassis	Power Steering Control Module																																																												
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2016	Tahoe	Chassis	Suspension Control Module																																																												
K	2016	Tahoe	Body	Body Control Module																																																												
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2016	Tahoe	Body	Passenger Presence Module																																																												
K	2016	Tahoe	Body	Instrument Cluster																																																												
K	2016	Tahoe	Body	Radio Controls																																																												
K	2016	Tahoe	Body	HVAC Controls																																																												
K	2016	Tahoe	Body	Radio																																																												
K	2016	Tahoe	Body	Amplifier																																																												
K	2016	Tahoe	Body	Media Disc Player																																																												
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																												
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																												
K	2016	Tahoe	Body	HVAC Control Module																																																												
K	2016	Tahoe	Body	Liftgate Control Module																																																						V	V	V	V			
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																												
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																												
K	2016	Tahoe	Body	Keyless Entry Control Module																																																												
K	2016	Tahoe	Body	Assist Step Control Module																																																												
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																												
K	2016	Tahoe	Body	Parking Assist Control Module																																																												
K	2016	Tahoe	Body	Frontview Camera Module																																																												
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																													
L	2004	ALL	Chassis	4WAL 3 Sensor																																																													
L	2004	ALL	Body	Body Control Module																																																												
L	2004	ALL	Body	Instrument Panel Cluster																																																												
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
L	2005	Astro	Chassis	4WAL 3 Sensor																																																												
L	2005	Astro	Body	Body Control Module																																																											
L	2005	Astro	Body	Instrument Panel Cluster																																																											
L	2005	Astro	Body	Supplemental Inflatable Restraint																																																											
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																											
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																											
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																																											
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																																											
L	2005	Equinox	Chassis	Electric Power Steering																																																											
L	2005	Equinox	Body	Body Control Module																																																											
L	2005	Equinox	Body	Instrument Panel Cluster																																																											
L	2005	Equinox	Body	Radio																																																											
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																																											
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																											
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																											
L	2006	ALL	Chassis	Traction Control Yes																																																											
L	2006	ALL	Chassis	Traction Control No																																																											
L	2006	ALL	Chassis	Electric Power Steering																																																											
L	2006	ALL	Body	Body Control Module																																																											
L	2006	ALL	Body	Instrument Panel Cluster																																																											
L	2006	ALL	Body	Radio																																																											
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																											
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																											
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																											
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																																											
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																																											
L	2007	ALL	Chassis	Power Steering Control Module																																																											
L	2007	ALL	Body	Body Control Module																																																											
L	2007	ALL	Body	Digital Radio Receiver																																																											
L	2007	ALL	Body	Heated Seat Module																																																											
L	2007	ALL	Body	HVAC Control Module																																																											
L	2007	ALL	Body	Instrument Panel Cluster																																																											
L	2007	ALL	Body	Passenger Presence System																																																											
L	2007	ALL	Body	Radio																																																											
L	2007	ALL	Body	Rollover Sensor																																																											
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2007	ALL	Body	Theft Deterrent Module																																																											
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																											
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																											
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																																														
L	2008	Captiva Sport	Body	Body Control Module																																																														
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																														
L	2008	Captiva Sport	Body	HVAC Control Module Auto																																																														
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																																														
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																																														
L	2008	Captiva Sport	Body	Passenger Presence System																																																														
L	2008	Captiva Sport	Body	Radio																																																														
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																																														
L	2008	Captiva Sport	Body	Rollover Sensor																																																														
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																																														
L	2008	Captiva Sport	Body	Theft Deterrent Module																																																														
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																														
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																														
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																														
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																														
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																														
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
L	2008	Equinox	Chassis	Electronic Brake Control Module																																																														
L	2008	Equinox	Chassis	Power Steering Control Module																																																														
L	2008	Equinox	Body	Body Control Module																																																														
L	2008	Equinox	Body	Digital Radio Receiver																																																														
L	2008	Equinox	Body	Heated Seat Module																																																														
L	2008	Equinox	Body	HVAC Control Module																																																														
L	2008	Equinox	Body	Instrument Panel Cluster																																																														
L	2008	Equinox	Body	Passenger Presence System																																																														
L	2008	Equinox	Body	Radio																																																														
L	2008	Equinox	Body	Rollover Sensor																																																														
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																																														
L	2008	Equinox	Body	Theft Deterrent Module																																																														
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module										V																																																				
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																														
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module										V																																																			
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																														
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																														
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																														
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																																														
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																														
L	2009	Captiva Sport	Body	Body Control Module																																																														
L	2009	Captiva Sport	Body	HVAC Control Module Auto																																																														
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																																														
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																																														
L	2009	Captiva Sport	Body	Passenger Presence System																																																														
L	2009	Captiva Sport	Body	Radio																																																														
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																																														
L	2009	Captiva Sport	Body	Rollover Sensor																																																														
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																																														
L	2009	Captiva Sport	Body	Theft Deterrent Module																																																														
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																													
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																													
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																													
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
L	2009	Equinox	Chassis	Electronic Brake Control Module																																																													
L	2009	Equinox	Chassis	Power Steering Control Module																																																													
L	2009	Equinox	Body	Body Control Module																																																													
L	2009	Equinox	Body	Digital Radio Receiver																																																													
L	2009	Equinox	Body	Heated Seat Module																																																													
L	2009	Equinox	Body	HVAC Control Module																																																													
L	2009	Equinox	Body	Instrument Panel Cluster																																																													
L	2009	Equinox	Body	Passenger Presence System																																																													
L	2009	Equinox	Body	Radio																																																													
L	2009	Equinox	Body	Rollover Sensor																																																													
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																																													
L	2009	Equinox	Body	Theft Deterrent Module																																																													
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module										V																																																			
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																													
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																													
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module										V																																																			
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																													
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																													
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																													
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																													
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																																													
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																													
L	2010	Captiva Sport	Body	Body Control Module																																																													
L	2010	Captiva Sport	Body	HVAC Control Module																																																													
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																																													
L	2010	Captiva Sport	Body	Passenger Presence System																																																													
L	2010	Captiva Sport	Body	Radio																																																													
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																																													
L	2010	Captiva Sport	Body	Rollover Sensor																																																													
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																																													
L	2010	Captiva Sport	Body	Theft Deterrent Module																																																													
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																													
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																													
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																													
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																													
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																													
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																													
L	2010	Equinox	Chassis	Electronic Brake Control Module																																																													
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																													
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																													
L	2010	Equinox	Body	Body Control Module																																																													
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
L	2010	Equinox	Body	Passenger Presence Module																																																													
L	2010	Equinox	Body	Instrument Cluster																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2010	Equinox	Body	Radio																																																												
L	2010	Equinox	Body	Multimedia Player Interface Module																																																												
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2010	Equinox	Body	Liftgate Control Module																																																												
L	2010	Equinox	Body	Parking Assist Control Module																																																												
L	2010	Equinox	Body	Frontview Camera Module																																																												
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																																												
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
L	2011	Captiva	Chassis	Electronic Brake Control Module																																																												
L	2011	Captiva	Chassis	Parking Brake Control Module																																																												
L	2011	Captiva	Body	Body Control Module																																																												
L	2011	Captiva	Body	Auxiliary Body Control Module																																																												
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2011	Captiva	Body	Instrument Cluster																																																												
L	2011	Captiva	Body	Headlamp Control Module																																																												
L	2011	Captiva	Body	HVAC Control Module																																																												
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																												
L	2011	Captiva	Body	Parking Assist Control Module																																																												
L	2011	Captiva	Body	Theft Deterrent Module																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module										V																																																		
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module										V																																																		
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module										V																																																		
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module																																																											
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																				V																							
L	2011	Captiva Sport	Body	Body Control Module															V	V	V	V	V	V	V																																					
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2011	Captiva Sport	Body	HVAC Control Module																																																										
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2011	Captiva Sport	Body	Passenger Presence System																																																										
L	2011	Captiva Sport	Body	Radio																																																										
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2011	Captiva Sport	Body	Rollover Sensor																																																										
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
L	2011	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																																											
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																											
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																											
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																											
L	2011	Equinox	Chassis	Electronic Brake Control Module																																																											
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2011	Equinox	Body	Body Control Module																																																										
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2011	Equinox	Body	Passenger Presence Module																																																											
L	2011	Equinox	Body	Instrument Cluster																																																											
L	2011	Equinox	Body	Radio																																																											
L	2011	Equinox	Body	Multimedia Player Interface Module																																																											
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											
L	2011	Equinox	Body	Liftgate Control Module																																																											
L	2011	Equinox	Body	Parking Assist Control Module																																																											
L	2011	Equinox	Body	Frontview Camera Module																																																											
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																																																											
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																											
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																											
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																											
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																											
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																											
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																											
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																												
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																												
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
L	2012	Captiva	Chassis	Electronic Brake Control Module																																																												
L	2012	Captiva	Chassis	Parking Brake Control Module																																																												
L	2012	Captiva	Body	Body Control Module																																					V									V	V												
L	2012	Captiva	Body	Auxiliary Body Control Module																																																												
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2012	Captiva	Body	Instrument Cluster																																																												
L	2012	Captiva	Body	Headlamp Control Module																																																												
L	2012	Captiva	Body	HVAC Control Module																																																												
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																												
L	2012	Captiva	Body	Parking Assist Control Module																																																												
L	2012	Captiva	Body	Theft Deterrent Module																																																												
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module										V																																																		
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																												
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																												
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																												
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module										V																																																		
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																												
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																												
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																												
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module																																																												
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																				V																								
L	2012	Captiva Sport	Body	Body Control Module														V	V	V	V	V	V	V																																								
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																												
L	2012	Captiva Sport	Body	HVAC Control Module																																																												
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																																												
L	2012	Captiva Sport	Body	Passenger Presence System																																																												
L	2012	Captiva Sport	Body	Radio																																																												
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2012	Captiva Sport	Body	Rollover Sensor																																																												
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
L	2012	Captiva Sport	Body	Theft Deterrent Module																																																												
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																												
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2012	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2012	Equinox	Body	Body Control Module																																																												
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2012	Equinox	Body	Passenger Presence Module																																																												
L	2012	Equinox	Body	Instrument Cluster																																																												
L	2012	Equinox	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2012	Equinox	Body	Multimedia Player Interface Module																																																														
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																													
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																													
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2012	Equinox	Body	Liftgate Control Module																																																												
L	2012	Equinox	Body	Parking Assist Control Module																																																												
L	2012	Equinox	Body	Frontview Camera Module																																																												
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																																												
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																												
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																												
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																												
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																												
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																												
L	2013	Captiva	Chassis	Parking Brake Control Module																																																												
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																				V							V	V													
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																				V							V	V													
L	2013	Captiva	Body	Auxiliary Body Control Module																																																												
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2013	Captiva	Body	Instrument Cluster																																																												
L	2013	Captiva	Body	Headlamp Control Module																																																												
L	2013	Captiva	Body	HVAC Control Module																																																												
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																												
L	2013	Captiva	Body	Theft Deterrent Module																																																												
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module										V																																																	
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																												
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																												
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module										V																																																	
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																												
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																												
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																																												
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																				V																							
L	2013	Captiva Sport	Body	Body Control Module															V	V	V	V	V	V	V																																						
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																												
L	2013	Captiva Sport	Body	Heated Seat Module																																																												
L	2013	Captiva Sport	Body	HVAC Control Module																																																												
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2013	Captiva Sport	Body	Park Assist Module																																																										
L	2013	Captiva Sport	Body	Passenger Presence System																																																										
L	2013	Captiva Sport	Body	Radio																																																										
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																										
L	2013	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2013	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2013	Equinox	Chassis	Power Steering Control Module																																																										
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2013	Equinox	Body	Passenger Presence Module																																																										
L	2013	Equinox	Body	Instrument Cluster																																																										
L	2013	Equinox	Body	Radio																																																										
L	2013	Equinox	Body	Rear Audio Control Module																																																										
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2013	Equinox	Body	Liftgate Control Module																																																										
L	2013	Equinox	Body	Front Seat Heating Control Module																																																										
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2013	Equinox	Body	Parking Assist Control Module																																																										
L	2013	Equinox	Body	Frontview Camera Module																																																										
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2014	Captiva (3GN)	Body	Body Control Module																																			V	V	V	V	V	V	V	V	V	V	V													
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																V										
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2014	Captiva (3GN)	Body	Radio																																																										
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																	V	V								
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																												
L	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																												
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																												
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																												
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																												
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																												
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																												
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																												
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																												
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																					V									V	V											
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																					V									V	V											
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2014	Captiva (Other)	Body	Instrument Cluster																																																												
L	2014	Captiva (Other)	Body	Headlamp Control Module																																																												
L	2014	Captiva (Other)	Body	HVAC Control Module																																																												
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																												
L	2014	Captiva (Other)	Body	Theft Deterrent Module																																																												
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2014	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2014	Equinox	Chassis	Power Steering Control Module																																																												
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																												
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2014	Equinox	Body	Passenger Presence Module																																																												
L	2014	Equinox	Body	Instrument Cluster																																																												
L	2014	Equinox	Body	Radio																																																											
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2014	Equinox	Body	Liftgate Control Module																																																				V	V	V	V		
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																									
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Parking Assist Control Module																																																										
L	2014	Equinox	Body	Frontview Camera Module																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (3GN)	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																																	V								
L	2015	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2015	Captiva (3GN)	Body	Radio																																																										
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
L	2015	Captiva (3GN)	Body	HVAC Control Module																																																		V	V							
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																				V								V	V										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																				V								V	V										
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (Other)	Body	Instrument Cluster																																																										
L	2015	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2015	Captiva (Other)	Body	HVAC Control Module																																																										
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
L	2015	Captiva (Other)	Body	Theft Deterrent Module																																																												
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2015	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2015	Equinox	Chassis	Power Steering Control Module																																																												
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																																												
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2015	Equinox	Body	Passenger Presence Module																																																												
L	2015	Equinox	Body	Instrument Cluster																																																												
L	2015	Equinox	Body	Radio																																																												
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																																												
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																																		V								
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2015	Equinox	Body	Liftgate Control Module																																																			V	V	V	V				
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																												
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																												
L	2015	Equinox	Body	Parking Assist Control Module																																																												
L	2015	Equinox	Body	Frontview Camera Module																																																												
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																												
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																												
L	2016	Captiva (3GN)	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2016	Captiva (3GN)	Body	Instrument Cluster																																																												
L	2016	Captiva (3GN)	Body	Radio																																																												
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																												
L	2016	Captiva (3GN)	Body	HVAC Control Module																																																			V	V							
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																												
L	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																												
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																				V									V	V										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																				V									V	V										
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Captiva (Other)	Body	Instrument Cluster																																																										
L	2016	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2016	Captiva (Other)	Body	Radio																																																										
L	2016	Captiva (Other)	Body	HVAC Control Module																																																										
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2016	Captiva (Other)	Body	Theft Deterrent Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2016	Equinox	Chassis	Power Steering Control Module																																																										
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Equinox	Body	Passenger Presence Module																																																										
L	2016	Equinox	Body	Instrument Cluster																																																										
L	2016	Equinox	Body	Radio																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2016	Equinox	Body	Liftgate Control Module																																																										
L	2016	Equinox	Body	Seat Memory Control Module																																																										
L	2016	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Parking Assist Control Module																																																										
L	2016	Equinox	Body	Frontview Camera Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
M	2004	ALL	Chassis	4WAL 3 Sensor																																																												
M	2004	ALL	Body	Body Control Module																																																												
M	2004	ALL	Body	Instrument Panel Cluster																																																												
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
M	2005	ALL	Chassis	4WAL 3 Sensor																																																												
M	2005	ALL	Body	Body Control Module																																																												
M	2005	ALL	Body	Instrument Panel Cluster																																																												
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																												
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																												
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																												
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
P	2007	ALL	Body	Theft Deterrent Module																																																												
R	2009	ALL	Powertrain	Engine Control Module																																																												
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2009	ALL	Powertrain	Transmission Control Module																																																												
R	2009	ALL	Chassis	Electronic Brake Control Module			V																																																								
R	2009	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																						
R	2009	ALL	Body	Digital Radio Receiver																																																											
R	2009	ALL	Body	Driver Door Switch																																																											
R	2009	ALL	Body	Heated Seat Module																																																											
R	2009	ALL	Body	HVAC Control Module Auto																																																											
R	2009	ALL	Body	HVAC Control Module Manual																																																											
R	2009	ALL	Body	Instrument Panel Cluster																																																											
R	2009	ALL	Body	Lift Gate Module																									V	V			V	V																													
R	2009	ALL	Body	Park Assist Module																																																										
R	2009	ALL	Body	Passenger Door Switch																																																											
R	2009	ALL	Body	Passenger Presence System																						V																																				
R	2009	ALL	Body	Radio																																																										
R	2009	ALL	Body	Rear HVAC/RSA																																																										
R	2009	ALL	Body	Rollover Sensor																																																										
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2009	ALL	Body	Theft Deterrent Module																																																											
R	2010	ALL	Powertrain	Engine Control Module																																																											
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2010	ALL	Powertrain	Transmission Control Module																																																											
R	2010	ALL	Chassis	Electronic Brake Control Module			V																																																							
R	2010	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																					
R	2010	ALL	Body	Digital Radio Receiver																																																											
R	2010	ALL	Body	Driver Door Switch																																																											
R	2010	ALL	Body	Heated Seat Module																																																											
R	2010	ALL	Body	HVAC Control Module Auto																																																											
R	2010	ALL	Body	HVAC Control Module Manual																																																											
R	2010	ALL	Body	Instrument Panel Cluster																																																											
R	2010	ALL	Body	Lift Gate Module																									V	V			V	V																													
R	2010	ALL	Body	Park Assist Module																																																										
R	2010	ALL	Body	Passenger Door Switch																																																											
R	2010	ALL	Body	Passenger Presence System																						V																																				
R	2010	ALL	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2010	ALL	Body	Rear HVAC/RSA																																																													
R	2010	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
R	2010	ALL	Body	Theft Deterrent Module																																																												
R	2011	ALL	Powertrain	Engine Control Module																																																													
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2011	ALL	Powertrain	Transmission Control Module																																																												
R	2011	ALL	Chassis	Electronic Brake Control Module			V																																																									
R	2011	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
R	2011	ALL	Body	Digital Radio Receiver																																																												
R	2011	ALL	Body	Driver Door Switch																																																												
R	2011	ALL	Body	Heated Seat Module																																																												
R	2011	ALL	Body	HVAC Control Module Auto																																																												
R	2011	ALL	Body	HVAC Control Module Manual																																																												
R	2011	ALL	Body	Instrument Panel Cluster																																																												
R	2011	ALL	Body	Lift Gate Module																									V	V			V	V																															
R	2011	ALL	Body	Park Assist Module																																																											
R	2011	ALL	Body	Passenger Door Switch																																																												
R	2011	ALL	Body	Passenger Presence System																						V																																							
R	2011	ALL	Body	Radio																																																												
R	2011	ALL	Body	Rear HVAC/RSA																																																												
R	2011	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
R	2011	ALL	Body	Theft Deterrent Module																																																												
R	2012	ALL	Powertrain	Engine Control Module										V																																																		
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2012	ALL	Powertrain	Transmission Control Module																																																												
R	2012	ALL	Chassis	Electronic Brake Control Module			V																																																									
R	2012	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
R	2012	ALL	Body	Digital Radio Receiver																																																												
R	2012	ALL	Body	Driver Door Switch																																																												
R	2012	ALL	Body	Heated Seat Module																																																												
R	2012	ALL	Body	HVAC Control Module Auto																																																												
R	2012	ALL	Body	HVAC Control Module Manual																																																												
R	2012	ALL	Body	Instrument Panel Cluster																																																												
R	2012	ALL	Body	Lift Gate Module																									V	V			V	V																															
R	2012	ALL	Body	Park Assist Module																																																												
R	2012	ALL	Body	Passenger Door Switch																																																												
R	2012	ALL	Body	Passenger Presence System																						V																																							
R	2012	ALL	Body	Radio																																																												
R	2012	ALL	Body	Rear HVAC/RSA																																																												
R	2012	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
R	2012	ALL	Body	Theft Deterrent Module																																																												
R	2013	ALL	Powertrain	Engine Control Module										V																																																		
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2013	ALL	Powertrain	Transmission Control Module																																																												
R	2013	ALL	Chassis	Electronic Brake Control Module			V																																																									
R	2013	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																						
R	2013	ALL	Body	Digital Radio Receiver																																																												
R	2013	ALL	Body	Driver Door Switch																																																												
R	2013	ALL	Body	Heated Seat Module																																																												
R	2013	ALL	Body	HVAC Control Module Auto																																																												
R	2013	ALL	Body	HVAC Control Module Manual																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2013	ALL	Body	Instrument Panel Cluster																																																										
R	2013	ALL	Body	Left Side Object Detection Module																																																										
R	2013	ALL	Body	Lift Gate Module																								V	V			V	V																													
R	2013	ALL	Body	Park Assist Module																																																										
R	2013	ALL	Body	Passenger Door Switch																																																										
R	2013	ALL	Body	Passenger Presence System																						V																																				
R	2013	ALL	Body	Radio																																																										
R	2013	ALL	Body	Rear HVAC/RSA																																																										
R	2013	ALL	Body	Right Side Object Detection Module																																																										
R	2013	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
R	2013	ALL	Body	Theft Deterrent Module																																																										
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2014	Traverse	Powertrain	Chassis Control Module																																																										
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2014	Traverse	Chassis	Electronic Brake Control Module																																																										
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																				V	V	V	V	V	V	V	V	V	V												
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																				V	V	V	V	V	V	V	V	V	V											
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2014	Traverse	Body	Passenger Presence Module																																																V										
R	2014	Traverse	Body	Instrument Cluster																																																										
R	2014	Traverse	Body	Radio																																																										
R	2014	Traverse	Body	Rear Audio Control Module																																																										
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																										
R	2014	Traverse	Body	Personal Audio Link Control Module																																																										
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																	V									
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																	V									
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																										
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
R	2014	Traverse	Body	Liftgate Control Module																																																			V	V	V	V				
R	2014	Traverse	Body	Seat Memory Control Module																																																									V	V
R	2014	Traverse	Body	Front Seat Heating Control Module																																																										
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2014	Traverse	Body	Parking Assist Control Module																																																										
R	2014	Traverse	Body	Frontview Camera Module																																																										
R	2014	Traverse	Body	Theft Deterrent Module																																																										
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2015	Traverse	Chassis	Electronic Brake Control Module																																																										
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																				V	V	V	V	V	V	V	V	V	V											
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																				V	V	V	V	V	V	V	V	V	V											
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	Traverse	Body	Passenger Presence Module																																																V										
R	2015	Traverse	Body	Instrument Cluster																																																										
R	2015	Traverse	Body	Radio																																																										
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2015	Traverse	Body	Liftgate Control Module																																																										
R	2015	Traverse	Body	Seat Memory Control Module																																																										
R	2015	Traverse	Body	Front Seat Heating Control Module																																																										
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2015	Traverse	Body	Parking Assist Control Module																																																										
R	2015	Traverse	Body	Frontview Camera Module																																																										
R	2015	Traverse	Body	Theft Deterrent Module																																																										
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2016	Traverse	Chassis	Electronic Brake Control Module																																																										
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																				V	V	V	V	V	V	V	V	V	V	V												
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																				V	V	V	V	V	V	V	V	V	V	V											
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Traverse	Body	Passenger Presence Module																																															V											
R	2016	Traverse	Body	Instrument Cluster																																																										
R	2016	Traverse	Body	Radio																																																										
R	2016	Traverse	Body	Rear Audio Control Module																																																										
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																										
R	2016	Traverse	Body	Personal Audio Link Control Module																																																										
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																										
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																V										
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																V										
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Traverse	Body	Liftgate Control Module																																																		V	V	V	V				
R	2016	Traverse	Body	Seat Memory Control Module																																																									V	V
R	2016	Traverse	Body	Front Seat Heating Control Module																																																										
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2016	Traverse	Body	Parking Assist Control Module																																																										
R	2016	Traverse	Body	Frontview Camera Module																																																										
R	2016	Traverse	Body	Theft Deterrent Module																																																										
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	S10	Chassis	4WAL 3 Sensor																																																										
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																										
S	2004	S10	Body	Body Control Module																																																										
S	2004	S10	Body	Instrument Panel Cluster																																																										
S	2004	S10	Body	Base Radio																																																										
S	2004	S10	Body	Uplevel Radio																																																										
S	2004	S10	Body	Supplemental Inflatable Restraint																																																										
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																													
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																													
S	2004	Colorado	Chassis	ABS Without Traction Control																																																													
S	2004	Colorado	Chassis	ABS With Traction Control																																																												
S	2004	Colorado	Body	Body Control Module																																																												
S	2004	Colorado	Body	Instrument Panel Cluster																																																												
S	2004	Colorado	Body	OnStar																																																												
S	2004	Colorado	Body	Base Radio																																																												
S	2004	Colorado	Body	Uplevel Radio																																																												
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																												
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																												
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																												
S	2004	TrailBlazer	Body	Body Control Module																																																												
S	2004	TrailBlazer	Body	Driver Door Module																																																												
S	2004	TrailBlazer	Body	Driver Seat Module																																																												
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																												
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																												
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2004	TrailBlazer	Body	Lift Gate Module																																																												
S	2004	TrailBlazer	Body	OnStar																																																												
S	2004	TrailBlazer	Body	Passenger Door Module																																																												
S	2004	TrailBlazer	Body	Uplevel Radio																																																												
S	2004	TrailBlazer	Body	Navigation Radio																																																												
S	2004	TrailBlazer	Body	Rear Seat Audio																																																												
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																												
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																												
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																												
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																												
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																												
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																												
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																												
S	2004	TrailBlazer EXT	Body	Body Control Module																																																												
S	2004	TrailBlazer EXT	Body	Driver Door Module																																																												
S	2004	TrailBlazer EXT	Body	Driver Seat Module																																																												
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																												
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																												
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																												
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																												
S	2004	TrailBlazer EXT	Body	OnStar																																																												
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																																												
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																												
S	2004	TrailBlazer EXT	Body	Navigation Radio																																																												
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																														
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																													
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																													
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																													
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																													
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																													
S	2004	Blazer	Body	Body Control Module																																																													
S	2004	Blazer	Body	Heating and Air Conditioning																																																													
S	2004	Blazer	Body	Instrument Panel Cluster																																																													
S	2004	Blazer	Body	Memory Seat Module																																																													
S	2004	Blazer	Body	Base Radio																																																													
S	2004	Blazer	Body	Uplevel Radio																																																													
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																																													
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																													
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																													
S	2004	SSR	Chassis	4WAL 3 Sensor																																																													
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																													
S	2004	SSR	Body	Amplifier (Bose)																																																													
S	2004	SSR	Body	Body Control Module																																																													
S	2004	SSR	Body	Driver Seat Module																																																													
S	2004	SSR	Body	Instrument Panel Cluster																																																													
S	2004	SSR	Body	Uplevel Radio																																																													
S	2004	SSR	Body	Remote Function Actuation																																																													
S	2004	SSR	Body	Roof and Door Module																																																													
S	2004	SSR	Body	Supplemental Inflatable Restraint																																																													
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																													
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																													
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																													
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																													
S	2005	Colorado	Chassis	ABS Without Traction Control																																																													
S	2005	Colorado	Chassis	ABS With Traction Control																																																													
S	2005	Colorado	Body	Body Control Module																																																													
S	2005	Colorado	Body	Instrument Panel Cluster																																																													
S	2005	Colorado	Body	Base Radio																																																													
S	2005	Colorado	Body	Uplevel Radio																																																													
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																																													
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																																													
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																													
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																													
S	2005	TrailBlazer	Body	Body Control Module																																																													
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																													
S	2005	TrailBlazer	Body	Driver Door Module																																																													
S	2005	TrailBlazer	Body	Driver Seat Module																																																													
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																													
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																													
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2005	TrailBlazer	Body	Lift Gate Module																																																													
S	2005	TrailBlazer	Body	Passenger Door Module																																																													
S	2005	TrailBlazer	Body	Passenger Presence System																																																													
S	2005	TrailBlazer	Body	Uplevel Radio																																																													
S	2005	TrailBlazer	Body	Navigation Radio																																																													
S	2005	TrailBlazer	Body	Rear Seat Audio																																																													
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																													
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																													
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																													
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																													
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																													
S	2005	TrailBlazer EXT	Body	Body Control Module																																																													
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																													
S	2005	TrailBlazer EXT	Body	Driver Door Module																																																													
S	2005	TrailBlazer EXT	Body	Driver Seat Module																																																													
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																													
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																													
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																													
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																													
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																																													
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																													
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																													
S	2005	TrailBlazer EXT	Body	Navigation Radio																																																													
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																													
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																													
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																													
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																													
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																													
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																													
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																													
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																													
S	2005	Blazer	Body	Body Control Module																																																													
S	2005	Blazer	Body	Heating and Air Conditioning																																																													
S	2005	Blazer	Body	Instrument Panel Cluster																																																													
S	2005	Blazer	Body	Memory Seat Module																																																													
S	2005	Blazer	Body	Base Radio																																																													
S	2005	Blazer	Body	Uplevel Radio																																																													
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																																													
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																													
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																													
S	2005	SSR	Chassis	4WAL 3 Sensor																																																													
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																													
S	2005	SSR	Body	Amplifier (Bose)																																																													
S	2005	SSR	Body	Body Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2005	SSR	Body	Driver Seat Module																																																															
S	2005	SSR	Body	Instrument Panel Cluster																																																														
S	2005	SSR	Body	Uplevel Radio																																																														
S	2005	SSR	Body	Remote Function Actuation																																																														
S	2005	SSR	Body	Roof and Door Module																																																														
S	2005	SSR	Body	Supplemental Inflatable Restraint																																																														
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																														
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																														
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																														
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																														
S	2006	Colorado	Chassis	ABS Without Traction Control																																																														
S	2006	Colorado	Chassis	ABS With Traction Control																																																														
S	2006	Colorado	Body	Body Control Module																																																														
S	2006	Colorado	Body	Instrument Panel Cluster																																																														
S	2006	Colorado	Body	Passenger Presence System																																																														
S	2006	Colorado	Body	Base Radio																																																														
S	2006	Colorado	Body	Uplevel Radio																																																														
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																																														
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																																														
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																														
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																														
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																														
S	2006	TrailBlazer	Body	Body Control Module																																																														
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																														
S	2006	TrailBlazer	Body	Driver Door Module																																																														
S	2006	TrailBlazer	Body	Driver Seat Module																																																														
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																														
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																														
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																																														
S	2006	TrailBlazer	Body	Lift Gate Module																																																														
S	2006	TrailBlazer	Body	Passenger Door Module																																																														
S	2006	TrailBlazer	Body	Passenger Presence System																																																														
S	2006	TrailBlazer	Body	Uplevel Radio																																																														
S	2006	TrailBlazer	Body	Navigation Radio																																																														
S	2006	TrailBlazer	Body	Rear Seat Audio																																																														
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																														
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																														
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																														
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																														
S	2006	TrailBlazer EXT	Body	Body Control Module																																																														
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																														
S	2006	TrailBlazer EXT	Body	Driver Door Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2006	TrailBlazer EXT	Body	Driver Seat Module																																																													
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																													
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																													
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																												
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																												
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																																												
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																												
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																												
S	2006	TrailBlazer EXT	Body	Navigation Radio																																																												
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																												
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																												
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																												
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																												
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																												
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																												
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2006	SSR	Chassis	4WAL 3 Sensor																																																												
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																												
S	2006	SSR	Body	Amplifier (Bose)																																																												
S	2006	SSR	Body	Body Control Module																																																												
S	2006	SSR	Body	Driver Seat Module																																																												
S	2006	SSR	Body	Instrument Panel Cluster																																																												
S	2006	SSR	Body	Uplevel Radio																																																												
S	2006	SSR	Body	Remote Function Actuation																																																												
S	2006	SSR	Body	Roof and Door Module																																																												
S	2006	SSR	Body	Supplemental Inflatable Restraint																																																												
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2007	Colorado	Body	Body Control Module																																																												
S	2007	Colorado	Body	Digital Radio Receiver																																																												
S	2007	Colorado	Body	Generator Battery Control Module																																																												
S	2007	Colorado	Body	Instrument Panel Cluster																																																												
S	2007	Colorado	Body	Passenger Presence System																																																												
S	2007	Colorado	Body	Base Radio																																																												
S	2007	Colorado	Body	Uplevel Radio																																																												
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																																												
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																												
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																												
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2007	Trailblazer	Body	Body Control Module																																																												
S	2007	Trailblazer	Body	Digital Radio Receiver																																																												
S	2007	Trailblazer	Body	Disc Player and Video Display																																																												
S	2007	Trailblazer	Body	Driver Door Module																																																												
S	2007	Trailblazer	Body	Driver Seat Module																																																												
S	2007	Trailblazer	Body	Generator Battery Control Module																																																												
S	2007	Trailblazer	Body	HVAC Control Module Auto																																																												
S	2007	Trailblazer	Body	HVAC Control Module Manual																																																												
S	2007	Trailblazer	Body	Instrument Panel Cluster																																																												
S	2007	Trailblazer	Body	Lift Gate Module																																																												
S	2007	Trailblazer	Body	Passenger Door Module																																																												
S	2007	Trailblazer	Body	Passenger Presence System																																																												
S	2007	Trailblazer	Body	Uplevel Radio																																																												
S	2007	Trailblazer	Body	Navigation Radio																																																												
S	2007	Trailblazer	Body	Rear Seat Audio																																																												
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																												
S	2007	Trailblazer	Body	Theft Deterrent Module																																																												
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																												
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2008	Colorado	Body	Body Control Module																																																												
S	2008	Colorado	Body	Digital Radio Receiver																																																												
S	2008	Colorado	Body	Generator Battery Control Module																																																												
S	2008	Colorado	Body	Instrument Panel Cluster																																																												
S	2008	Colorado	Body	Passenger Presence System																																																												
S	2008	Colorado	Body	Base Radio																																																												
S	2008	Colorado	Body	Uplevel Radio																																																												
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2008	Colorado	Body	Theft Deterrent Module																																																												
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																																												
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
S	2008	TrailBlazer	Body	Body Control Module																																																												
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																												
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																												
S	2008	TrailBlazer	Body	Driver Door Module																																																												
S	2008	TrailBlazer	Body	Driver Seat Module																																																												
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																												
S	2008	TrailBlazer	Body	HVAC Control Module Auto																																																												
S	2008	TrailBlazer	Body	HVAC Control Module Manual																																																												
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2008	TrailBlazer	Body	Lift Gate Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2008	TrailBlazer	Body	Passenger Door Module																																																															
S	2008	TrailBlazer	Body	Passenger Presence System																																																															
S	2008	TrailBlazer	Body	Uplevel Radio																																																															
S	2008	TrailBlazer	Body	Navigation Radio																																																															
S	2008	TrailBlazer	Body	Rear Seat Audio																																																															
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																															
S	2008	TrailBlazer	Body	Theft Deterrent Module																																																															
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																															
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																					
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																																
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																																
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																					
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																																
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																																
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module										V																																																					
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																																
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																																
S	2009	Colorado	Chassis	Electronic Brake Control Module																																																																
S	2009	Colorado	Body	Body Control Module																																																																
S	2009	Colorado	Body	Digital Radio Receiver																																																																
S	2009	Colorado	Body	Generator Battery Control Module																																																																
S	2009	Colorado	Body	Instrument Panel Cluster																																																																
S	2009	Colorado	Body	Passenger Presence System																																																																
S	2009	Colorado	Body	Base Radio																																																																
S	2009	Colorado	Body	Uplevel Radio																																																																
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																																																
S	2009	Colorado	Body	Theft Deterrent Module																																																																
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module										V																																																					
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																																
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																																
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																					
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																																
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																																
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module										V																																																					
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																																
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																																
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																																
S	2009	TrailBlazer	Body	Body Control Module																																																																
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																																
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																																
S	2009	TrailBlazer	Body	Driver Door Module																																																																
S	2009	TrailBlazer	Body	Driver Seat Module																																																																
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																																
S	2009	TrailBlazer	Body	HVAC Control Module Auto																																																																
S	2009	TrailBlazer	Body	HVAC Control Module Manual																																																																
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																																																
S	2009	TrailBlazer	Body	Lift Gate Module																																																																
S	2009	TrailBlazer	Body	Passenger Door Module																																																																
S	2009	TrailBlazer	Body	Passenger Presence System																																																																
S	2009	TrailBlazer	Body	Uplevel Radio																																																																
S	2009	TrailBlazer	Body	Navigation Radio																																																																

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2009	TrailBlazer	Body	Rear Seat Audio																																																															
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																														
S	2009	TrailBlazer	Body	Theft Deterrent Module																																																														
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																				
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																					
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module										V																																																					
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																															
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																															
S	2010	ALL	Chassis	Electronic Brake Control Module																																																																
S	2010	ALL	Body	Body Control Module																																																																
S	2010	ALL	Body	Digital Radio Receiver																																																																
S	2010	ALL	Body	Generator Battery Control Module																																																																
S	2010	ALL	Body	Instrument Panel Cluster																																																																
S	2010	ALL	Body	Passenger Presence System																																																																
S	2010	ALL	Body	Personal Audio Link Module																																																																
S	2010	ALL	Body	Base Radio																																																																
S	2010	ALL	Body	Uplevel Radio																																																																
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																																
S	2010	ALL	Body	Theft Deterrent Module																																																																
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																																
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																					
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																																
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																																
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																					
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																																
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																																
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module										V																																																					
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																																
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																																
S	2011	ALL	Chassis	Electronic Brake Control Module																																																																
S	2011	ALL	Body	Body Control Module																																																																
S	2011	ALL	Body	Digital Radio Receiver																																																																
S	2011	ALL	Body	Generator Battery Control Module																																																																
S	2011	ALL	Body	Instrument Panel Cluster																																																																
S	2011	ALL	Body	Passenger Presence System																																																																
S	2011	ALL	Body	Personal Audio Link Module																																																																
S	2011	ALL	Body	Base Radio																																																																
S	2011	ALL	Body	Uplevel Radio																																																																
S	2011	ALL	Body	Supplemental Inflatable Restraint																																																																
S	2011	ALL	Body	Theft Deterrent Module																																																																
S	2011	ALL	Body	Vehicle Comm. Interface Module																																																																
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																					
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																																
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																																
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																					
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																																
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																																

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module										V																																																			
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																													
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																													
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																													
S	2012	Colorado (First Gen)	Body	Body Control Module																																																													
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																													
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																													
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																													
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																													
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																													
S	2012	Colorado (First Gen)	Body	Base Radio																																																													
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																													
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																													
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																													
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																													
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																													
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																													
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																													
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																													
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																													
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																													
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																													
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																													
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																													
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																													
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																													
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																													
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																													
S	2012	Colorado (Second Gen)	Body	Body Control Module																																																													
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																													
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																													
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																													
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																													
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																													
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																													
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																													
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																													
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																													
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																													
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																													
S	2012	S10	Powertrain	Transfer Case Control Module																																																													
S	2012	S10	Chassis	Electronic Brake Control Module																																																													
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																													
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																													
S	2012	S10	Body	Body Control Module																																																													
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2012	S10	Body	Instrument Cluster																																																													
S	2012	S10	Body	Trailer Interface Control Module																																																													
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																													
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																												
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																												
S	2013	Colorado	Powertrain	Transfer Case Control Module																																																												
S	2013	Colorado	Chassis	Electronic Brake Control Module																																																												
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2013	Colorado	Body	Body Control Module																																																												
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2013	Colorado	Body	Instrument Cluster																																																												
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																												
S	2013	S10	Powertrain	Transfer Case Control Module																																																												
S	2013	S10	Chassis	Electronic Brake Control Module																																																												
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2013	S10	Body	Body Control Module																																																												
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2013	S10	Body	Instrument Cluster																																																												
S	2013	S10	Body	Trailer Interface Control Module																																																												
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																												
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																												
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																												
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																												
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2013	Trailblazer	Body	Body Control Module																																																												
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2013	Trailblazer	Body	Instrument Cluster																																																												
S	2013	Trailblazer	Body	Trailer Interface Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2013	Trailblazer	Body	Parking Assist Control Module																																																														
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																														
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																														
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																														
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																														
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																														
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																														
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																														
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																														
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2014	Colorado	Body	Body Control Module																																																														
S	2014	Colorado	Body	Body Control Module																																																														
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2014	Colorado	Body	Instrument Cluster																																																														
S	2014	Colorado	Body	Radio																																																														
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																														
S	2014	Colorado	Body	Parking Assist Control Module																																																														
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																														
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																														
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																														
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																														
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																														
S	2014	S10	Powertrain	Transfer Case Control Module																																																														
S	2014	S10	Chassis	Electronic Brake Control Module																																																														
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2014	S10	Body	Body Control Module																																																														
S	2014	S10	Body	Body Control Module																																																														
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2014	S10	Body	Instrument Cluster																																																														
S	2014	S10	Body	Trailer Interface Control Module																																																														
S	2014	S10	Body	Radio																																																														
S	2014	S10	Body	Parking Assist Control Module																																																														
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																														
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																														
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																														
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																														
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																														
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2014	Trailblazer	Body	Body Control Module																																																														
S	2014	Trailblazer	Body	Body Control Module																																																														
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2014	Trailblazer	Body	Instrument Cluster																																																														
S	2014	Trailblazer	Body	Trailer Interface Control Module																																																														
S	2014	Trailblazer	Body	Parking Assist Control Module																																																														
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																														
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																														
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																														
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																														
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																														
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
S	2015	Colorado	Powertrain	Chassis Control Module																																																														
S	2015	Colorado	Powertrain	Transfer Case Control Module																																																														
S	2015	Colorado	Chassis	Electronic Brake Control Module																																																														
S	2015	Colorado	Chassis	Power Steering Control Module																																																														
S	2015	Colorado	Body	Body Control Module																																																														
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2015	Colorado	Body	Passenger Presence Module																																																														
S	2015	Colorado	Body	Radio																																																														
S	2015	Colorado	Body	Amplifier																																																														
S	2015	Colorado	Body	Human Machine Interface Control Module																																																														
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																																														
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																														
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																														
S	2015	Colorado	Body	Frontview Camera Module																																																														
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																														
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																														
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																														
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2015	Colorado (MMM)	Body	Body Control Module																																																														
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2015	Colorado (MMM)	Body	Instrument Cluster																																																												
S	2015	Colorado (MMM)	Body	Radio																																																												
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																												
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																												
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2015	S10	Powertrain	Transfer Case Control Module																																																												
S	2015	S10	Chassis	Electronic Brake Control Module																																																												
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2015	S10	Body	Body Control Module																																																												
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2015	S10	Body	Instrument Cluster																																																												
S	2015	S10	Body	Trailer Interface Control Module																																																												
S	2015	S10	Body	Radio																																																												
S	2015	S10	Body	Telematics Communication Interface Control Module																																																												
S	2015	S10	Body	Parking Assist Control Module																																																												
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																												
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																												
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2015	Trailblazer	Body	Body Control Module																																																												
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2015	Trailblazer	Body	Instrument Cluster																																																												
S	2015	Trailblazer	Body	Trailer Interface Control Module																																																												
S	2015	Trailblazer	Body	Radio																																																												
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																												
S	2015	Trailblazer	Body	Parking Assist Control Module																																																												
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																												
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																												
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																												
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																												
S	2016	Colorado (1GC)	Body	Body Control Module																																																												
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																																												
S	2016	Colorado (1GC)	Body	Radio Controls																																																												
S	2016	Colorado (1GC)	Body	HVAC Controls																																																												
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																												
S	2016	Colorado (1GC)	Body	Radio																																																												
S	2016	Colorado (1GC)	Body	Amplifier																																																												
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																												
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																												
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																												
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																				V							
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																												
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																																												
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																												
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																												
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2016	Colorado (MMM)	Body	Body Control Module																																																												
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2016	Colorado (MMM)	Body	Instrument Cluster																																																												
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																												
S	2016	Colorado (MMM)	Body	Radio																																																												
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																												
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																				V							
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																												
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																												
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																												
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
S	2016	S10	Powertrain	Transfer Case Control Module																																																												
S	2016	S10	Chassis	Electronic Brake Control Module																																																												
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2016	S10	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2016	S10	Body	Instrument Cluster																																																														
S	2016	S10	Body	Trailer Interface Control Module																																																														
S	2016	S10	Body	Radio																																																														
S	2016	S10	Body	Telematics Communication Interface Control Module																																																														
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																														
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																														
S	2016	S10	Body	Parking Assist Control Module																																																														
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																														
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																														
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																														
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																														
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																														
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2016	Trailblazer	Body	Body Control Module																																																														
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2016	Trailblazer	Body	Instrument Cluster																																																														
S	2016	Trailblazer	Body	Trailer Interface Control Module																																																														
S	2016	Trailblazer	Body	Radio																																																														
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																														
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																														
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																														
S	2016	Trailblazer	Body	Parking Assist Control Module																																																														
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																														
T	2004	S10	Chassis	4WAL 3 Sensor																																																														
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																														
T	2004	S10	Body	Body Control Module																																																														
T	2004	S10	Body	Instrument Panel Cluster																																																														
T	2004	S10	Body	Base Radio																																																														
T	2004	S10	Body	Uplevel Radio																																																														
T	2004	S10	Body	Supplemental Inflatable Restraint																																																														
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																														
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																														
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																														
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																														
T	2004	Colorado	Chassis	ABS Without Traction Control																																																														
T	2004	Colorado	Chassis	ABS With Traction Control																																																														
T	2004	Colorado	Body	Body Control Module																																																														
T	2004	Colorado	Body	Instrument Panel Cluster																																																														
T	2004	Colorado	Body	OnStar																																																														
T	2004	Colorado	Body	Base Radio																																																														
T	2004	Colorado	Body	Uplevel Radio																																																														
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																																														
T	2004	Colorado	Body	Instrument Panel Cluster																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																													
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																													
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																													
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																													
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																													
T	2004	TrailBlazer	Body	Body Control Module																																																													
T	2004	TrailBlazer	Body	Driver Door Module																																																													
T	2004	TrailBlazer	Body	Driver Seat Module																																																													
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																													
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																													
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																																													
T	2004	TrailBlazer	Body	Lift Gate Module																																																													
T	2004	TrailBlazer	Body	OnStar																																																													
T	2004	TrailBlazer	Body	Passenger Door Module																																																													
T	2004	TrailBlazer	Body	Uplevel Radio																																																													
T	2004	TrailBlazer	Body	Navigation Radio																																																													
T	2004	TrailBlazer	Body	Rear Seat Audio																																																													
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																													
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																													
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																													
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																													
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																													
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																													
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																													
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																													
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																													
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																													
T	2004	TrailBlazer EXT	Body	Body Control Module																																																													
T	2004	TrailBlazer EXT	Body	Driver Door Module																																																													
T	2004	TrailBlazer EXT	Body	Driver Seat Module																																																													
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																													
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																													
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																													
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																													
T	2004	TrailBlazer EXT	Body	OnStar																																																													
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																																													
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																													
T	2004	TrailBlazer EXT	Body	Navigation Radio																																																													
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																													
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																													
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																													
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																													
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																													
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																													
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																													
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																												
T	2004	Blazer	Body	Body Control Module																																																												
T	2004	Blazer	Body	Heating and Air Conditioning																																																												
T	2004	Blazer	Body	Instrument Panel Cluster																																																												
T	2004	Blazer	Body	Memory Seat Module																																																												
T	2004	Blazer	Body	Base Radio																																																												
T	2004	Blazer	Body	Uplevel Radio																																																												
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																																												
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2005	Colorado	Chassis	ABS Without Traction Control																																																												
T	2005	Colorado	Chassis	ABS With Traction Control																																																												
T	2005	Colorado	Body	Body Control Module																																																												
T	2005	Colorado	Body	Instrument Panel Cluster																																																												
T	2005	Colorado	Body	Base Radio																																																												
T	2005	Colorado	Body	Uplevel Radio																																																												
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																																												
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																																												
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																												
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																												
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																												
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																												
T	2005	TrailBlazer	Body	Body Control Module																																																												
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																												
T	2005	TrailBlazer	Body	Driver Door Module																																																												
T	2005	TrailBlazer	Body	Driver Seat Module																																																												
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																												
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																												
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																																												
T	2005	TrailBlazer	Body	Lift Gate Module																																																												
T	2005	TrailBlazer	Body	Passenger Door Module																																																												
T	2005	TrailBlazer	Body	Passenger Presence System																																																												
T	2005	TrailBlazer	Body	Uplevel Radio																																																												
T	2005	TrailBlazer	Body	Navigation Radio																																																												
T	2005	TrailBlazer	Body	Rear Seat Audio																																																												
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																												
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																												
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																															
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																															
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																															
T	2005	TrailBlazer EXT	Body	Body Control Module																																																															
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																															
T	2005	TrailBlazer EXT	Body	Driver Door Module																																																															
T	2005	TrailBlazer EXT	Body	Driver Seat Module																																																															
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																															
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																															
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																															
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																															
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																																															
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																															
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																															
T	2005	TrailBlazer EXT	Body	Navigation Radio																																																															
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																															
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																															
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																															
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																															
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																															
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																															
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																															
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																															
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																															
T	2005	Blazer	Body	Body Control Module																																																															
T	2005	Blazer	Body	Heating and Air Conditioning																																																															
T	2005	Blazer	Body	Instrument Panel Cluster																																																															
T	2005	Blazer	Body	Memory Seat Module																																																															
T	2005	Blazer	Body	Base Radio																																																															
T	2005	Blazer	Body	Uplevel Radio																																																															
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																																															
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																															
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																															
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																															
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																															
T	2006	Colorado	Chassis	ABS Without Traction Control																																																															
T	2006	Colorado	Chassis	ABS With Traction Control																																																															
T	2006	Colorado	Body	Body Control Module																																																															
T	2006	Colorado	Body	Instrument Panel Cluster																																																															
T	2006	Colorado	Body	Passenger Presence System																																																															
T	2006	Colorado	Body	Base Radio																																																															
T	2006	Colorado	Body	Uplevel Radio																																																															
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																																															
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																																															
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																															
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																													
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																													
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																													
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																													
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																													
T	2006	TrailBlazer	Body	Body Control Module																																																													
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																													
T	2006	TrailBlazer	Body	Driver Door Module																																																													
T	2006	TrailBlazer	Body	Driver Seat Module																																																													
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																													
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																													
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																																													
T	2006	TrailBlazer	Body	Lift Gate Module																																																													
T	2006	TrailBlazer	Body	Passenger Door Module																																																													
T	2006	TrailBlazer	Body	Passenger Presence System																																																													
T	2006	TrailBlazer	Body	Uplevel Radio																																																													
T	2006	TrailBlazer	Body	Navigation Radio																																																													
T	2006	TrailBlazer	Body	Rear Seat Audio																																																													
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																													
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																													
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																													
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																													
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																													
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																													
T	2006	TrailBlazer EXT	Body	Body Control Module																																																													
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																													
T	2006	TrailBlazer EXT	Body	Driver Door Module																																																													
T	2006	TrailBlazer EXT	Body	Driver Seat Module																																																													
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																													
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																													
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																													
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																													
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																																													
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																													
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																													
T	2006	TrailBlazer EXT	Body	Navigation Radio																																																													
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																													
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																													
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																													
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																													
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																													
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																													
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																													
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																													
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																													
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																													
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																														
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																														
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																														
T	2007	Colorado	Body	Body Control Module																																																														
T	2007	Colorado	Body	Digital Radio Receiver																																																														
T	2007	Colorado	Body	Generator Battery Control Module																																																														
T	2007	Colorado	Body	Instrument Panel Cluster																																																														
T	2007	Colorado	Body	Passenger Presence System																																																														
T	2007	Colorado	Body	Base Radio																																																														
T	2007	Colorado	Body	Uplevel Radio																																																														
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																																														
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																																														
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																														
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																														
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																														
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																														
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																														
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																														
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																														
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																														
T	2007	Trailblazer	Body	Body Control Module																																																														
T	2007	Trailblazer	Body	Digital Radio Receiver																																																														
T	2007	Trailblazer	Body	Disc Player and Video Display																																																														
T	2007	Trailblazer	Body	Driver Door Module																																																														
T	2007	Trailblazer	Body	Driver Seat Module																																																														
T	2007	Trailblazer	Body	Generator Battery Control Module																																																														
T	2007	Trailblazer	Body	HVAC Control Module Auto																																																														
T	2007	Trailblazer	Body	HVAC Control Module Manual																																																														
T	2007	Trailblazer	Body	Instrument Panel Cluster																																																														
T	2007	Trailblazer	Body	Lift Gate Module																																																														
T	2007	Trailblazer	Body	Passenger Door Module																																																														
T	2007	Trailblazer	Body	Passenger Presence System																																																														
T	2007	Trailblazer	Body	Uplevel Radio																																																														
T	2007	Trailblazer	Body	Navigation Radio																																																														
T	2007	Trailblazer	Body	Rear Seat Audio																																																														
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																														
T	2007	Trailblazer	Body	Theft Deterrent Module																																																														
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																														
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																														
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																														
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																														
T	2008	Colorado	Body	Body Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2008	Colorado	Body	Digital Radio Receiver																																																															
T	2008	Colorado	Body	Generator Battery Control Module																																																															
T	2008	Colorado	Body	Instrument Panel Cluster																																																															
T	2008	Colorado	Body	Passenger Presence System																																																															
T	2008	Colorado	Body	Base Radio																																																															
T	2008	Colorado	Body	Uplevel Radio																																																															
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																																															
T	2008	Colorado	Body	Theft Deterrent Module																																																															
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																																															
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																															
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																															
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																															
T	2008	TrailBlazer	Body	Body Control Module																																																															
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																															
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																															
T	2008	TrailBlazer	Body	Driver Door Module																																																															
T	2008	TrailBlazer	Body	Driver Seat Module																																																															
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																															
T	2008	TrailBlazer	Body	HVAC Control Module Auto																																																															
T	2008	TrailBlazer	Body	HVAC Control Module Manual																																																															
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																																															
T	2008	TrailBlazer	Body	Lift Gate Module																																																															
T	2008	TrailBlazer	Body	Passenger Door Module																																																															
T	2008	TrailBlazer	Body	Passenger Presence System																																																															
T	2008	TrailBlazer	Body	Uplevel Radio																																																															
T	2008	TrailBlazer	Body	Navigation Radio																																																															
T	2008	TrailBlazer	Body	Rear Seat Audio																																																															
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																															
T	2008	TrailBlazer	Body	Theft Deterrent Module																																																															
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																															
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																					
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																															
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																					
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																															
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module										V																																																				
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																															
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																															
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																															
T	2009	Colorado	Chassis	Electronic Brake Control Module																																																															
T	2009	Colorado	Body	Body Control Module																																																															
T	2009	Colorado	Body	Digital Radio Receiver																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2009	Colorado	Body	Generator Battery Control Module																																																														
T	2009	Colorado	Body	Instrument Panel Cluster																																																													
T	2009	Colorado	Body	Passenger Presence System																																																													
T	2009	Colorado	Body	Base Radio																																																													
T	2009	Colorado	Body	Uplevel Radio																																																													
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																																													
T	2009	Colorado	Body	Theft Deterrent Module																																																													
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module										V																																																			
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																													
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																			
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																													
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module										V																																																			
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																													
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																													
T	2009	TrailBlazer	Body	Body Control Module																																																													
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																													
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																													
T	2009	TrailBlazer	Body	Driver Door Module																																																													
T	2009	TrailBlazer	Body	Driver Seat Module																																																													
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																													
T	2009	TrailBlazer	Body	HVAC Control Module Auto																																																													
T	2009	TrailBlazer	Body	HVAC Control Module Manual																																																													
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																																													
T	2009	TrailBlazer	Body	Lift Gate Module																																																													
T	2009	TrailBlazer	Body	Passenger Door Module																																																													
T	2009	TrailBlazer	Body	Passenger Presence System																																																													
T	2009	TrailBlazer	Body	Uplevel Radio																																																													
T	2009	TrailBlazer	Body	Navigation Radio																																																													
T	2009	TrailBlazer	Body	Rear Seat Audio																																																													
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																													
T	2009	TrailBlazer	Body	Theft Deterrent Module																																																													
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																			
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																													
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																													
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																													
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																			
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																													
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																													
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																													
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module										V																																																			
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																													
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																													
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																													
T	2010	ALL	Chassis	Electronic Brake Control Module																																																													
T	2010	ALL	Body	Body Control Module																																																													
T	2010	ALL	Body	Digital Radio Receiver																																																													
T	2010	ALL	Body	Generator Battery Control Module																																																													
T	2010	ALL	Body	Instrument Panel Cluster																																																													
T	2010	ALL	Body	Passenger Presence System																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2010	ALL	Body	Personal Audio Link Module																																																														
T	2010	ALL	Body	Base Radio																																																														
T	2010	ALL	Body	Uplevel Radio																																																														
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																														
T	2010	ALL	Body	Theft Deterrent Module																																																														
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																														
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																				
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																															
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																				
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																															
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module										V																																																				
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																															
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																															
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																															
T	2011	ALL	Chassis	Electronic Brake Control Module																																																															
T	2011	ALL	Body	Body Control Module																																																															
T	2011	ALL	Body	Digital Radio Receiver																																																															
T	2011	ALL	Body	Generator Battery Control Module																																																															
T	2011	ALL	Body	Instrument Panel Cluster																																																															
T	2011	ALL	Body	Passenger Presence System																																																															
T	2011	ALL	Body	Personal Audio Link Module																																																															
T	2011	ALL	Body	Base Radio																																																															
T	2011	ALL	Body	Uplevel Radio																																																															
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																															
T	2011	ALL	Body	Theft Deterrent Module																																																															
T	2011	ALL	Body	Vehicle Comm. Interface Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																					
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																				
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module										V																																																				
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																															
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																															
T	2012	Colorado (First Gen)	Body	Body Control Module																																																															
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																															
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																															
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																															
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																															
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																															
T	2012	Colorado (First Gen)	Body	Base Radio																																																															
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																													
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																													
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																													
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																													
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																													
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																													
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																													
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																													
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																													
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																													
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																													
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																													
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																													
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																													
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2012	Colorado (Second Gen)	Body	Body Control Module																																																														
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																													
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																													
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																													
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																													
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																													
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																													
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																													
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																													
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																													
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																													
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																													
T	2012	S10	Powertrain	Transfer Case Control Module																																																													
T	2012	S10	Chassis	Electronic Brake Control Module																																																													
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2012	S10	Body	Body Control Module																																																													
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2012	S10	Body	Instrument Cluster																																																													
T	2012	S10	Body	Trailer Interface Control Module																																																													
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																													
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																													
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																													
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																													
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																													
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																													
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																													
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																													
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																													
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																													
T	2013	Colorado	Powertrain	Transfer Case Control Module																																																													
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																													
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2013	Colorado	Body	Body Control Module																																																												
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2013	Colorado	Body	Instrument Cluster																																																												
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																												
T	2013	S10	Powertrain	Transfer Case Control Module																																																												
T	2013	S10	Chassis	Electronic Brake Control Module																																																												
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2013	S10	Body	Body Control Module																																																												
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2013	S10	Body	Instrument Cluster																																																												
T	2013	S10	Body	Trailer Interface Control Module																																																												
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																												
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																												
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																												
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																												
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2013	Trailblazer	Body	Body Control Module																																																												
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2013	Trailblazer	Body	Instrument Cluster																																																												
T	2013	Trailblazer	Body	Trailer Interface Control Module																																																												
T	2013	Trailblazer	Body	Parking Assist Control Module																																																												
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																												
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																												
T	2014	Colorado	Powertrain	Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																														
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																														
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																														
T	2014	Colorado	Body	Body Control Module																																																														
T	2014	Colorado	Body	Body Control Module																																																														
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
T	2014	Colorado	Body	Instrument Cluster																																																														
T	2014	Colorado	Body	Radio																																																														
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																														
T	2014	Colorado	Body	Parking Assist Control Module																																																														
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																														
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																														
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																														
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																														
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																														
T	2014	S10	Powertrain	Transfer Case Control Module																																																														
T	2014	S10	Chassis	Electronic Brake Control Module																																																														
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																														
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																														
T	2014	S10	Body	Body Control Module																																																														
T	2014	S10	Body	Body Control Module																																																														
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
T	2014	S10	Body	Instrument Cluster																																																														
T	2014	S10	Body	Trailer Interface Control Module																																																														
T	2014	S10	Body	Radio																																																														
T	2014	S10	Body	Parking Assist Control Module																																																														
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																														
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																														
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																														
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																														
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																														
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																														
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																														
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																														
T	2014	Trailblazer	Body	Body Control Module																																																														
T	2014	Trailblazer	Body	Body Control Module																																																														
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
T	2014	Trailblazer	Body	Instrument Cluster																																																														
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																														
T	2014	Trailblazer	Body	Parking Assist Control Module																																																														
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																														
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																														
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2015	Colorado	Powertrain	Chassis Control Module																																																											
T	2015	Colorado	Powertrain	Transfer Case Control Module																																																											
T	2015	Colorado	Chassis	Electronic Brake Control Module																																																											
T	2015	Colorado	Chassis	Power Steering Control Module																																																											
T	2015	Colorado	Body	Body Control Module																																																											
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2015	Colorado	Body	Passenger Presence Module																																																											
T	2015	Colorado	Body	Radio																																																										
T	2015	Colorado	Body	Amplifier																																																										
T	2015	Colorado	Body	Human Machine Interface Control Module																																																											
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																																											
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																										
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																											
T	2015	Colorado	Body	Frontview Camera Module																																																											
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																											
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																											
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2015	Colorado (MMM)	Body	Body Control Module																																																											
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2015	Colorado (MMM)	Body	Instrument Cluster																																																											
T	2015	Colorado (MMM)	Body	Radio																																																											
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																											
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																											
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																											
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																											
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																													
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																													
T	2015	S10	Powertrain	Transfer Case Control Module																																																													
T	2015	S10	Chassis	Electronic Brake Control Module																																																													
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2015	S10	Body	Body Control Module																																																													
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2015	S10	Body	Instrument Cluster																																																													
T	2015	S10	Body	Trailer Interface Control Module																																																													
T	2015	S10	Body	Radio																																																													
T	2015	S10	Body	Telematics Communication Interface Control Module																																																													
T	2015	S10	Body	Parking Assist Control Module																																																													
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																													
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																													
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																													
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																													
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																													
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																													
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																													
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																													
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																													
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2015	Trailblazer	Body	Body Control Module																																																													
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2015	Trailblazer	Body	Instrument Cluster																																																													
T	2015	Trailblazer	Body	Trailer Interface Control Module																																																													
T	2015	Trailblazer	Body	Radio																																																													
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																													
T	2015	Trailblazer	Body	Parking Assist Control Module																																																													
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																													
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																													
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																													
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																													
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																													
T	2016	Colorado (1GC)	Body	Body Control Module																																																													
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																																													
T	2016	Colorado (1GC)	Body	Radio Controls																																																													
T	2016	Colorado (1GC)	Body	HVAC Controls																																																													
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																													
T	2016	Colorado (1GC)	Body	Radio																																																													
T	2016	Colorado (1GC)	Body	Amplifier																																																													
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																												
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																												
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																												V				
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																												
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																												
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																												
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2016	Colorado (MMM)	Body	Body Control Module																																																												
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																												
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																												
T	2016	Colorado (MMM)	Body	Radio																																																												
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																												
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																											V				
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																												
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																												
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
T	2016	S10	Powertrain	Transfer Case Control Module																																																												
T	2016	S10	Chassis	Electronic Brake Control Module																																																												
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2016	S10	Body	Body Control Module																																																												
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	S10	Body	Instrument Cluster																																																												
T	2016	S10	Body	Trailer Interface Control Module																																																												
T	2016	S10	Body	Radio																																																											
T	2016	S10	Body	Telematics Communication Interface Control Module																																																												
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																												V				
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	S10	Body	Parking Assist Control Module																																																												
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																												
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																												
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2016	Trailblazer	Body	Body Control Module																																																												
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	Trailblazer	Body	Instrument Cluster																																																												
T	2016	Trailblazer	Body	Trailer Interface Control Module																																																												
T	2016	Trailblazer	Body	Radio																																																												
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																												
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																												
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	Trailblazer	Body	Parking Assist Control Module																																																												
V	2009	ALL	Powertrain	Engine Control Module																																																												
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2009	ALL	Powertrain	Rear Drive System																																																												
V	2009	ALL	Powertrain	Transmission Control Module																																																												
V	2009	ALL	Chassis	Electronic Brake Control Module			V																																																									
V	2009	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
V	2009	ALL	Body	Digital Radio Receiver																																																												
V	2009	ALL	Body	Driver Door Switch																																																												
V	2009	ALL	Body	Heated Seat Module																																																												
V	2009	ALL	Body	HVAC Control Module Auto																																																												
V	2009	ALL	Body	HVAC Control Module Manual																																																												
V	2009	ALL	Body	Instrument Panel Cluster																																																												
V	2009	ALL	Body	Lift Gate Module																									V	V			V	V																														
V	2009	ALL	Body	Park Assist Module																																																												
V	2009	ALL	Body	Passenger Door Switch																																																												
V	2009	ALL	Body	Passenger Presence System																						V																																						
V	2009	ALL	Body	Radio																																																												
V	2009	ALL	Body	Rear HVAC/RSA																																																												
V	2009	ALL	Body	Rollover Sensor																																																												
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2009	ALL	Body	Theft Deterrent Module																																																												
V	2010	ALL	Powertrain	Engine Control Module																																																												
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2010	ALL	Powertrain	Rear Drive System																																																												
V	2010	ALL	Powertrain	Transmission Control Module																																																												
V	2010	ALL	Chassis	Electronic Brake Control Module			V																																																									
V	2010	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
V	2010	ALL	Body	Digital Radio Receiver																																																												
V	2010	ALL	Body	Driver Door Switch																																																												
V	2010	ALL	Body	Heated Seat Module																																																												
V	2010	ALL	Body	HVAC Control Module Auto																																																												
V	2010	ALL	Body	HVAC Control Module Manual																																																												
V	2010	ALL	Body	Instrument Panel Cluster																																																												
V	2010	ALL	Body	Lift Gate Module																									V	V			V	V																														
V	2010	ALL	Body	Park Assist Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
V	2010	ALL	Body	Passenger Door Switch																																																										
V	2010	ALL	Body	Passenger Presence System																						V																																				
V	2010	ALL	Body	Radio																																																									
V	2010	ALL	Body	Rear HVAC/RSA																																																									
V	2010	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
V	2010	ALL	Body	Theft Deterrent Module																																																									
V	2011	ALL	Powertrain	Engine Control Module																																																									
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2011	ALL	Powertrain	Rear Drive System																																																									
V	2011	ALL	Powertrain	Transmission Control Module																																																									
V	2011	ALL	Chassis	Electronic Brake Control Module			V																																																							
V	2011	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																					
V	2011	ALL	Body	Digital Radio Receiver																																																										
V	2011	ALL	Body	Driver Door Switch																																																									
V	2011	ALL	Body	Heated Seat Module																																																									
V	2011	ALL	Body	HVAC Control Module Auto																																																									
V	2011	ALL	Body	HVAC Control Module Manual																																																									
V	2011	ALL	Body	Instrument Panel Cluster																																																									
V	2011	ALL	Body	Lift Gate Module																									V	V			V	V																													
V	2011	ALL	Body	Park Assist Module																																																									
V	2011	ALL	Body	Passenger Door Switch																																																									
V	2011	ALL	Body	Passenger Presence System																						V																																				
V	2011	ALL	Body	Radio																																																									
V	2011	ALL	Body	Rear HVAC/RSA																																																									
V	2011	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
V	2011	ALL	Body	Theft Deterrent Module																																																									
V	2012	ALL	Powertrain	Engine Control Module										V																																															
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2012	ALL	Powertrain	Rear Drive System																																																									
V	2012	ALL	Powertrain	Transmission Control Module																																																									
V	2012	ALL	Chassis	Electronic Brake Control Module			V																																																						
V	2012	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																				
V	2012	ALL	Body	Digital Radio Receiver																																																									
V	2012	ALL	Body	Driver Door Switch																																																									
V	2012	ALL	Body	Heated Seat Module																																																									
V	2012	ALL	Body	HVAC Control Module Auto																																																									
V	2012	ALL	Body	HVAC Control Module Manual																																																									
V	2012	ALL	Body	Instrument Panel Cluster																																																									
V	2012	ALL	Body	Lift Gate Module																									V	V			V	V																													
V	2012	ALL	Body	Park Assist Module																																																									
V	2012	ALL	Body	Passenger Door Switch																																																									
V	2012	ALL	Body	Passenger Presence System																						V																																				
V	2012	ALL	Body	Radio																																																									
V	2012	ALL	Body	Rear HVAC/RSA																																																									
V	2012	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
V	2012	ALL	Body	Theft Deterrent Module																																																									
V	2013	ALL	Powertrain	Engine Control Module										V																																															
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2013	ALL	Powertrain	Rear Drive System																																																									
V	2013	ALL	Powertrain	Transmission Control Module																																																									
V	2013	ALL	Chassis	Electronic Brake Control Module			V																																																						

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
V	2013	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																					
V	2013	ALL	Body	Digital Radio Receiver																																																											
V	2013	ALL	Body	Driver Door Switch																																																											
V	2013	ALL	Body	Heated Seat Module																																																											
V	2013	ALL	Body	HVAC Control Module Auto																																																											
V	2013	ALL	Body	HVAC Control Module Manual																																																											
V	2013	ALL	Body	Instrument Panel Cluster																																																											
V	2013	ALL	Body	Left Side Object Detection Module																																																											
V	2013	ALL	Body	Lift Gate Module																									V	V			V	V																														
V	2013	ALL	Body	Park Assist Module																																																										
V	2013	ALL	Body	Passenger Door Switch																																																											
V	2013	ALL	Body	Passenger Presence System																						V																																					
V	2013	ALL	Body	Radio																																																											
V	2013	ALL	Body	Rear HVAC/RSA																																																											
V	2013	ALL	Body	Right Side Object Detection Module																																																											
V	2013	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
V	2013	ALL	Body	Theft Deterrent Module																																																											
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2014	Traverse	Powertrain	Chassis Control Module																																																											
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																											
V	2014	Traverse	Chassis	Electronic Brake Control Module																																																											
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																			V	V	V	V	V	V	V	V	V	V													
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																			V	V	V	V	V	V	V	V	V	V													
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
V	2014	Traverse	Body	Passenger Presence Module																																																V										
V	2014	Traverse	Body	Instrument Cluster																																																											
V	2014	Traverse	Body	Radio																																																											
V	2014	Traverse	Body	Rear Audio Control Module																																																											
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																											
V	2014	Traverse	Body	Personal Audio Link Control Module																																																											
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																											
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																											
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																V										
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																V										
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																											
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																											
V	2014	Traverse	Body	Liftgate Control Module																																																				V	V	V	V					
V	2014	Traverse	Body	Seat Memory Control Module																																																								V	V
V	2014	Traverse	Body	Front Seat Heating Control Module																																																											
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																											
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																											
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																											
V	2014	Traverse	Body	Parking Assist Control Module																																																											
V	2014	Traverse	Body	Frontview Camera Module																																																											
V	2014	Traverse	Body	Theft Deterrent Module																																																											
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																											
V	2015	Traverse	Chassis	Electronic Brake Control Module																																																											
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate						V																													V	V	V	V	V	V	V	V	V	V													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																				V	V	V	V	V	V	V	V	V	V	V										
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2015	Traverse	Body	Passenger Presence Module																																															V									
V	2015	Traverse	Body	Instrument Cluster																																																								
V	2015	Traverse	Body	Radio																																																								
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																								
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																								
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																								
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																V								
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																V								
V	2015	Traverse	Body	Liftgate Control Module																																																		V	V	V	V			
V	2015	Traverse	Body	Seat Memory Control Module																																																						V	V
V	2015	Traverse	Body	Front Seat Heating Control Module																																																								
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																								
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																								
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																								
V	2015	Traverse	Body	Parking Assist Control Module																																																								
V	2015	Traverse	Body	Frontview Camera Module																																																								
V	2015	Traverse	Body	Theft Deterrent Module																																																								
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																								
V	2016	Traverse	Chassis	Electronic Brake Control Module																																																								
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																				V	V	V	V	V	V	V	V	V	V										
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																				V	V	V	V	V	V	V	V	V	V										
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
V	2016	Traverse	Body	Passenger Presence Module																																															V								
V	2016	Traverse	Body	Instrument Cluster																																																								
V	2016	Traverse	Body	Radio																																																								
V	2016	Traverse	Body	Rear Audio Control Module																																																								
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																								
V	2016	Traverse	Body	Personal Audio Link Control Module																																																								
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																								
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																V								
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																V								
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																								
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																								
V	2016	Traverse	Body	Liftgate Control Module																																																		V	V	V	V			
V	2016	Traverse	Body	Seat Memory Control Module																																																					V	V
V	2016	Traverse	Body	Front Seat Heating Control Module																																																								
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																								
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																								
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																								
V	2016	Traverse	Body	Parking Assist Control Module																																																								
V	2016	Traverse	Body	Frontview Camera Module																																																								
V	2016	Traverse	Body	Theft Deterrent Module																																																								
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																								
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																													
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																													
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																													
A	2011	Orlando	Chassis	Parking Brake Control Module																																																												
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2011	Orlando	Chassis	Power Steering Control Module																																																												
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2011	Orlando	Body	Body Control Module																																																												
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2011	Orlando	Body	Instrument Cluster																																																												
A	2011	Orlando	Body	Trailer Interface Control Module																																																												
A	2011	Orlando	Body	Radio																																																												
A	2011	Orlando	Body	Multimedia Player Interface Module																																																												
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																			V								
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																			V								
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																			V								
A	2011	Orlando	Body	Keyless Entry Control Module																																																												
A	2011	Orlando	Body	Parking Assist Control Module																																																												
A	2011	Orlando	Body	Steering Column Lock Control Module																																																												
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																												
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																												
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																												
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																												
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																												
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																												
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																												
A	2012	Orlando	Chassis	Parking Brake Control Module																																																												
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2012	Orlando	Chassis	Power Steering Control Module																																																												
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2012	Orlando	Body	Body Control Module																																																												
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2012	Orlando	Body	Instrument Cluster																																																												
A	2012	Orlando	Body	Trailer Interface Control Module																																																												
A	2012	Orlando	Body	Radio																																																											
A	2012	Orlando	Body	Multimedia Player Interface Module																																																												
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																												
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																			V								
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																			V								
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																			V								
A	2012	Orlando	Body	Keyless Entry Control Module																																																												
A	2012	Orlando	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2012	Orlando	Body	Steering Column Lock Control Module																																																												
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																												
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																												
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																												
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																												
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																												
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																												
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																												
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																												
A	2013	Orlando	Chassis	Parking Brake Control Module																																																												
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2013	Orlando	Chassis	Power Steering Control Module																																																												
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2013	Orlando	Body	Body Control Module																																																												
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2013	Orlando	Body	Instrument Cluster																																																												
A	2013	Orlando	Body	Radio																																																											
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																											
A	2013	Orlando	Body	Multimedia Player Interface Module																																																											
A	2013	Orlando	Body	Mobile Telephone Control Module																																																											
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																											
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																											
A	2013	Orlando	Body	Front Seat Heating Control Module																																																											
A	2013	Orlando	Body	Keyless Entry Control Module																																																											
A	2013	Orlando	Body	Parking Assist Control Module																																																											
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																													
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																													
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																													
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																													
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																													
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																													
A	2014	Orlando	Chassis	Power Steering Control Module																																																													
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2014	Orlando	Body	Body Control Module																																																													
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2014	Orlando	Body	Instrument Cluster																																																													
A	2014	Orlando	Body	Radio																																																													
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																													
A	2014	Orlando	Body	Multimedia Player Interface Module																																																													
A	2014	Orlando	Body	Mobile Telephone Control Module																																																													
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																													
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																													
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																													
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																													
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																													
A	2014	Orlando	Body	Front Seat Heating Control Module																																																													
A	2014	Orlando	Body	Rear Seat Heating Control Module																																																													
A	2014	Orlando	Body	Keyless Entry Control Module																																																													
A	2014	Orlando	Body	Parking Assist Control Module																																																													
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																													
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																													
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																													
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																													
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																													
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																													
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																													
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																													
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																													
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																													
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																													
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																													
A	2015	Orlando	Chassis	Power Steering Control Module																																																													
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2015	Orlando	Body	Body Control Module																																																													
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2015	Orlando	Body	Instrument Cluster																																																													
A	2015	Orlando	Body	Radio																																																													
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																													
A	2015	Orlando	Body	Mobile Telephone Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																													
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																			V								
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																			V								
A	2015	Orlando	Body	Front Seat Heating Control Module																																																												
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																												
A	2015	Orlando	Body	Keyless Entry Control Module																																																												
A	2015	Orlando	Body	Parking Assist Control Module																																																												
A	2015	Orlando	Body	Frontview Camera Module																																																												
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																												
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																												
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																												
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																												
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																												
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																												
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																												
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																												
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																												
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2016	Orlando	Chassis	Power Steering Control Module																																																												
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2016	Orlando	Body	Body Control Module																																																												
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2016	Orlando	Body	Instrument Cluster																																																												
A	2016	Orlando	Body	Radio																																																											
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																											
A	2016	Orlando	Body	Multimedia Player Interface Module																																																											
A	2016	Orlando	Body	Mobile Telephone Control Module																																																											
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																											
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																					V								
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																			V								
A	2016	Orlando	Body	Front Seat Heating Control Module																																																												
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																												
A	2016	Orlando	Body	Keyless Entry Control Module																																																												
A	2016	Orlando	Body	Parking Assist Control Module																																																												
A	2016	Orlando	Body	Frontview Camera Module																																																												
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																																																												
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																																																												
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																																																												
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																																																												
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																																																												
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2009	N200	Chassis	Electronic Brake Control Module																																																												
C	2009	N200	Body	Supplemental Inflatable Restraint																																																												
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2009	N300	Chassis	Electronic Brake Control Module																																																												
C	2009	N300	Body	Supplemental Inflatable Restraint																																																												
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2010	N200	Chassis	Electronic Brake Control Module																																																												
C	2010	N200	Body	Supplemental Inflatable Restraint																																																												
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2010	N300	Chassis	Electronic Brake Control Module																																																												
C	2010	N300	Body	Supplemental Inflatable Restraint																																																												
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2011	N200	Chassis	Electronic Brake Control Module																																																												
C	2011	N200	Body	Supplemental Inflatable Restraint																																																												
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2011	N300	Chassis	Electronic Brake Control Module																																																												
C	2011	N300	Body	Supplemental Inflatable Restraint																																																												
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2012	N200	Chassis	Electronic Brake Control Module																																																												
C	2012	N200	Body	Supplemental Inflatable Restraint																																																												
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2012	N300	Chassis	Electronic Brake Control Module																																																												
C	2012	N300	Body	Supplemental Inflatable Restraint																																																												
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2013	N300	Chassis	Electronic Brake Control Module																																																												
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																																												
C	2014	N300	Chassis	Electronic Brake Control Module																																																												
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																																												
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																																												
C	2015	Max	Chassis	Electronic Brake Control Module																																																												
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																																												
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																																												
C	2015	Move	Chassis	Electronic Brake Control Module																																																												
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																																												
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																																												
C	2015	N300	Chassis	Electronic Brake Control Module																																																												
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module																																																														
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																																														
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																																														
C	2016	Max	Chassis	Electronic Brake Control Module																																																														
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module																																																														
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																																														
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																																														
C	2016	Move	Chassis	Electronic Brake Control Module																																																														
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module																																																														
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																																														
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																																														
C	2016	N300	Chassis	Electronic Brake Control Module																																																														
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																														
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																														
M	2015	City Express	Chassis	Electronic Brake Control Module																																																														
M	2015	City Express	Chassis	Power Steering Control Module																																																														
M	2015	City Express	Body	Body Control Module																																																														
M	2015	City Express	Body	Underhood Fuse Block																																																														
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2015	City Express	Body	Instrument Cluster																																																														
M	2015	City Express	Body	Tire Pressure Indicator Module																																																														
M	2015	City Express	Body	Radio																																																														
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																														
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																														
M	2016	City Express	Chassis	Electronic Brake Control Module																																																														
M	2016	City Express	Chassis	Power Steering Control Module																																																														
M	2016	City Express	Body	Body Control Module																																																														
M	2016	City Express	Body	Underhood Fuse Block																																																														
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2016	City Express	Body	Instrument Cluster																																																														
M	2016	City Express	Body	Tire Pressure Indicator Module																																																														
M	2016	City Express	Body	Radio																																																														
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																														
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																														
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																														
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																														
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																														
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																														
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																														
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																														
P	2011	Orlando	Chassis	Parking Brake Control Module																																																														
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																														
P	2011	Orlando	Chassis	Power Steering Control Module																																																														
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
P	2011	Orlando	Body	Body Control Module																																																											
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2011	Orlando	Body	Instrument Cluster																																																											
P	2011	Orlando	Body	Trailer Interface Control Module																																																											
P	2011	Orlando	Body	Radio																																																										
P	2011	Orlando	Body	Multimedia Player Interface Module																																																											
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2011	Orlando	Body	Keyless Entry Control Module																																																											
P	2011	Orlando	Body	Parking Assist Control Module																																																											
P	2011	Orlando	Body	Steering Column Lock Control Module																																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																											
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2012	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2012	Orlando	Chassis	Parking Brake Control Module																																																											
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2012	Orlando	Chassis	Power Steering Control Module																																																											
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2012	Orlando	Body	Body Control Module																																																											
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2012	Orlando	Body	Instrument Cluster																																																											
P	2012	Orlando	Body	Trailer Interface Control Module																																																											
P	2012	Orlando	Body	Radio																																																											
P	2012	Orlando	Body	Multimedia Player Interface Module																																																											
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2012	Orlando	Body	Keyless Entry Control Module																																																											
P	2012	Orlando	Body	Parking Assist Control Module																																																											
P	2012	Orlando	Body	Steering Column Lock Control Module																																																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																												
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																												
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																												
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																												
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																												
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																												
P	2013	Orlando	Chassis	Parking Brake Control Module																																																												
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2013	Orlando	Chassis	Power Steering Control Module																																																												
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2013	Orlando	Body	Body Control Module																																																												
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2013	Orlando	Body	Instrument Cluster																																																												
P	2013	Orlando	Body	Radio																																																											
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																											
P	2013	Orlando	Body	Multimedia Player Interface Module																																																											
P	2013	Orlando	Body	Mobile Telephone Control Module																																																											
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																											
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																											
P	2013	Orlando	Body	Front Seat Heating Control Module																																																											
P	2013	Orlando	Body	Keyless Entry Control Module																																																											
P	2013	Orlando	Body	Parking Assist Control Module																																																											
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
P	2014	Orlando	Chassis	Power Steering Control Module																																																													
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																													
P	2014	Orlando	Body	Body Control Module																																																													
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
P	2014	Orlando	Body	Instrument Cluster																																																													
P	2014	Orlando	Body	Radio																																																													
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																													
P	2014	Orlando	Body	Multimedia Player Interface Module																																																													
P	2014	Orlando	Body	Mobile Telephone Control Module																																																													
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																													
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																													
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																					V							
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																													
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																					V							
P	2014	Orlando	Body	Front Seat Heating Control Module																																																													
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																													
P	2014	Orlando	Body	Keyless Entry Control Module																																																													
P	2014	Orlando	Body	Parking Assist Control Module																																																													
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																													
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																													
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																													
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																													
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																													
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																													
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																													
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																													
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																													
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																													
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																													
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																													
P	2015	Orlando	Chassis	Power Steering Control Module																																																													
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																													
P	2015	Orlando	Body	Body Control Module																																																													
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
P	2015	Orlando	Body	Instrument Cluster																																																													
P	2015	Orlando	Body	Radio																																																													
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																													
P	2015	Orlando	Body	Mobile Telephone Control Module																																																													
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																													
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																					V							
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																													
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																					V							
P	2015	Orlando	Body	Front Seat Heating Control Module																																																													
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																													
P	2015	Orlando	Body	Keyless Entry Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
P	2015	Orlando	Body	Parking Assist Control Module																																																												
P	2015	Orlando	Body	Frontview Camera Module																																																												
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																												
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																												
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																												
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																												
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																												
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																												
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																												
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2016	Orlando	Chassis	Power Steering Control Module																																																												
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2016	Orlando	Body	Body Control Module																																																												
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2016	Orlando	Body	Instrument Cluster																																																												
P	2016	Orlando	Body	Radio																																																												
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																												
P	2016	Orlando	Body	Multimedia Player Interface Module																																																												
P	2016	Orlando	Body	Mobile Telephone Control Module																																																												
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																																												
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																												
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																												
P	2016	Orlando	Body	Front Seat Heating Control Module																																																												
P	2016	Orlando	Body	Rear Seat Heating Control Module																																																												
P	2016	Orlando	Body	Keyless Entry Control Module																																																												
P	2016	Orlando	Body	Parking Assist Control Module																																																												
P	2016	Orlando	Body	Frontview Camera Module																																																												
U	2004	ALL	Powertrain	Engine Control Module																																																												
U	2004	ALL	Powertrain	Transmission Control Module																																																												
U	2004	ALL	Body	Digital Radio Receiver																																																												
U	2004	ALL	Body	Driver Information Center																																																											
U	2004	ALL	Body	Instrument Panel Cluster																																																												
U	2004	ALL	Body	Radio																																																												
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
U	2004	ALL	Body	Vehicle Theft Deterrent																																																												
U	2005	ALL	Powertrain	Engine Control Module																																																												
U	2005	ALL	Powertrain	Transmission Control Module																																																												
U	2005	ALL	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
U	2005	ALL	Body	Body Control Module																																																															
U	2005	ALL	Body	Disc Player and Video																																																															
U	2005	ALL	Body	Digital Radio Receiver																																																															
U	2005	ALL	Body	HVAC Control Module																																																															
U	2005	ALL	Body	Instrument Panel Cluster																																																															
U	2005	ALL	Body	Left Power Sliding Door Module																																																															
U	2005	ALL	Body	Mobile Digital Media																																																															
U	2005	ALL	Body	Navigation Radio																																																															
U	2005	ALL	Body	Navigation Radio																																																															
U	2005	ALL	Body	Radio																																																															
U	2005	ALL	Body	Right Power Sliding Door Module																																																															
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																															
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																															
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																															
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																															
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																															
U	2006	ALL	Chassis	Electronic Brake Control Module																																																															
U	2006	ALL	Body	Body Control Module																																																															
U	2006	ALL	Body	Disc Player and Video																																																															
U	2006	ALL	Body	Digital Radio Receiver																																																															
U	2006	ALL	Body	HVAC Control Module																																																															
U	2006	ALL	Body	Instrument Panel Cluster																																																															
U	2006	ALL	Body	Left Power Sliding Door Module																																																															
U	2006	ALL	Body	Mobile Digital Media																																																															
U	2006	ALL	Body	Navigation Radio																																																															
U	2006	ALL	Body	Navigation Radio																																																															
U	2006	ALL	Body	Radio																																																															
U	2006	ALL	Body	Right Power Sliding Door Module																																																															
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																															
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																															
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																															
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																															
U	2007	ALL	Chassis	Electronic Brake Control Module																																																															
U	2007	ALL	Body	Body Control Module																																																															
U	2007	ALL	Body	Digital Radio Receiver																																																															
U	2007	ALL	Body	Disc Player and Video Display																																																															
U	2007	ALL	Body	HVAC Control Module																																																															
U	2007	ALL	Body	Left Power Sliding Door Module																																																															
U	2007	ALL	Body	Mobile Digital Media																																																															
U	2007	ALL	Body	Radio																																																															
U	2007	ALL	Body	Navigation Radio																																																															
U	2007	ALL	Body	Right Power Sliding Door Module																																																															
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																															
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																															
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																															
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																															
U	2008	ALL	Chassis	Electronic Brake Control Module																																																															
U	2008	ALL	Body	Body Control Module																																																															
U	2008	ALL	Body	Digital Radio Receiver																																																															
U	2008	ALL	Body	Disc Player and Video Display																																																															
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																													
U	2008	ALL	Body	Left Power Sliding Door Module																																																													
U	2008	ALL	Body	Radio																																																												
U	2008	ALL	Body	Navigation Radio																																																												
U	2008	ALL	Body	Remote Control Door Lock Receiver																																																												
U	2008	ALL	Body	Right Power Sliding Door Module																																																												
U	2009	ALL	Powertrain	Engine Control Module																																																												
U	2009	ALL	Powertrain	Transmission Control Module																																																												
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																												
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																												
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																												
U	2009	ALL	Body	Body Control Module																																																												
U	2009	ALL	Body	Digital Radio Receiver																																																												
U	2009	ALL	Body	Disc Player and Video Display																																																												
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																																												
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																												
U	2009	ALL	Body	Instrument Panel Cluster																																																												
U	2009	ALL	Body	Left Power Sliding Door Module																																																												
U	2009	ALL	Body	Radio																																																												
U	2009	ALL	Body	Remote Control Door Lock Receiver																																																												
U	2009	ALL	Body	Right Power Sliding Door Module																																																												
V	2004	ALL	Powertrain	Engine Data Display																																																												
V	2004	ALL	Powertrain	Transmission Data Display																																																												
V	2004	ALL	Body	Digital Radio Receiver																																																												
V	2004	ALL	Body	Driver Information Center																																																												
V	2004	ALL	Body	Instrument Panel Cluster																																																												
V	2004	ALL	Body	Radio																																																												
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2004	ALL	Body	Vehicle Theft Deterrent																																																												
V	2005	Venture	Powertrain	Engine Control Module																																																												
V	2005	Venture	Powertrain	Transmission Control Module																																																												
V	2005	Venture	Body	Digital Radio Receiver																																																												
V	2005	Venture	Body	Driver Information Center																																																												
V	2005	Venture	Body	Instrument Panel Cluster																																																												
V	2005	Venture	Body	Radio																																																												
V	2005	Venture	Body	Supplemental Inflatable Restraint																																																												
V	2005	Venture	Body	Vehicle Theft Deterrent																																																												
V	2005	Uplander	Powertrain	Engine Control Module																																																												
V	2005	Uplander	Powertrain	Transmission Control Module																																																												
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																												
V	2005	Uplander	Body	Body Control Module																																																												
V	2005	Uplander	Body	Disc Player and Video																																																												
V	2005	Uplander	Body	Digital Radio Receiver																																																												
V	2005	Uplander	Body	HVAC Control Module																																																												
V	2005	Uplander	Body	Instrument Panel Cluster																																																												
V	2005	Uplander	Body	Left Power Sliding Door Module																																																												
V	2005	Uplander	Body	Mobile Digital Media																																																												
V	2005	Uplander	Body	Navigation Radio																																																												
V	2005	Uplander	Body	Navigation Radio																																																												
V	2005	Uplander	Body	Radio																																																												
V	2005	Uplander	Body	Right Power Sliding Door Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
V	2005	Uplander	Body	Supplemental Inflatable Restraint																																																											
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																											
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																											
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																											
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																											
V	2006	ALL	Chassis	Electronic Brake Control Module																																																											
V	2006	ALL	Body	Body Control Module																																																											
V	2006	ALL	Body	Disc Player and Video																																																											
V	2006	ALL	Body	Digital Radio Receiver																																																											
V	2006	ALL	Body	HVAC Control Module																																																											
V	2006	ALL	Body	Instrument Panel Cluster																																																											
V	2006	ALL	Body	Left Power Sliding Door Module																																																											
V	2006	ALL	Body	Mobile Digital Media																																																											
V	2006	ALL	Body	Navigation Radio																																																											
V	2006	ALL	Body	Navigation Radio																																																											
V	2006	ALL	Body	Radio																																																											
V	2006	ALL	Body	Right Power Sliding Door Module																																																											
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																											
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																											
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																											
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																											
V	2007	ALL	Chassis	Electronic Brake Control Module																																																											
V	2007	ALL	Body	Body Control Module																																																											
V	2007	ALL	Body	Digital Radio Receiver																																																											
V	2007	ALL	Body	Disc Player and Video Display																																																											
V	2007	ALL	Body	HVAC Control Module																																																											
V	2007	ALL	Body	Left Power Sliding Door Module																																																											
V	2007	ALL	Body	Mobile Digital Media																																																											
V	2007	ALL	Body	Radio																																																											
V	2007	ALL	Body	Navigation Radio																																																											
V	2007	ALL	Body	Right Power Sliding Door Module																																																											
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																											
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																											
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																											
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																											
V	2008	ALL	Chassis	Electronic Brake Control Module																																																											
V	2008	ALL	Body	Body Control Module																																																											
V	2008	ALL	Body	Digital Radio Receiver																																																											
V	2008	ALL	Body	Disc Player and Video Display																																																											
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																																											
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																											
V	2008	ALL	Body	Left Power Sliding Door Module																																																											
V	2008	ALL	Body	Radio																																																											
V	2008	ALL	Body	Navigation Radio																																																											
V	2008	ALL	Body	Remote Control Door Lock Receiver																																																											
V	2008	ALL	Body	Right Power Sliding Door Module																																																											
V	2009	ALL	Powertrain	Engine Control Module																																																											
V	2009	ALL	Powertrain	Transmission Control Module																																																											
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																											
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																											
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
V	2009	ALL	Body	Body Control Module																																																											
V	2009	ALL	Body	Digital Radio Receiver																																																											
V	2009	ALL	Body	Disc Player and Video Display																																																											
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																																											
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																											
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																											
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																											
V	2009	ALL	Body	Left Power Sliding Door Module																																																											
V	2009	ALL	Body	Radio																																																											
V	2009	ALL	Body	Remote Control Door Lock Receiver																																																											
V	2009	ALL	Body	Right Power Sliding Door Module																																																											
X	2004	ALL	Powertrain	Engine Control Module																																																											
X	2004	ALL	Powertrain	Transmission Control Module																																																											
X	2004	ALL	Body	Digital Radio Receiver																																																											
X	2004	ALL	Body	Driver Information Center																																																											
X	2004	ALL	Body	Instrument Panel Cluster																																																											
X	2004	ALL	Body	Radio																																																											
X	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
X	2004	ALL	Body	Vehicle Theft Deterrent																																																											
X	2005	ALL	Powertrain	Engine Control Module																																																											
X	2005	ALL	Powertrain	Transmission Control Module																																																											
X	2005	ALL	Chassis	Electronic Brake Control Module																																																											
X	2005	ALL	Body	Body Control Module																																																											
X	2005	ALL	Body	Disc Player and Video																																																											
X	2005	ALL	Body	Digital Radio Receiver																																																											
X	2005	ALL	Body	HVAC Control Module																																																											
X	2005	ALL	Body	Instrument Panel Cluster																																																											
X	2005	ALL	Body	Left Power Sliding Door Module																																																											
X	2005	ALL	Body	Mobile Digital Media																																																											
X	2005	ALL	Body	Navigation Radio																																																											
X	2005	ALL	Body	Navigation Radio																																																											
X	2005	ALL	Body	Radio																																																											
X	2005	ALL	Body	Right Power Sliding Door Module																																																											
X	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																											
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																											
X	2006	ALL	Chassis	Electronic Brake Control Module																																																											
X	2006	ALL	Body	Body Control Module																																																											
X	2006	ALL	Body	Disc Player and Video																																																											
X	2006	ALL	Body	Digital Radio Receiver																																																											
X	2006	ALL	Body	HVAC Control Module																																																											
X	2006	ALL	Body	Instrument Panel Cluster																																																											
X	2006	ALL	Body	Left Power Sliding Door Module																																																											
X	2006	ALL	Body	Mobile Digital Media																																																											
X	2006	ALL	Body	Navigation Radio																																																											
X	2006	ALL	Body	Navigation Radio																																																											
X	2006	ALL	Body	Radio																																																											
X	2006	ALL	Body	Right Power Sliding Door Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2006	ALL	Powertrain	Transmission Control Module																																																										
A	2006	ALL	Chassis	Electronic Brake Control Module																																																										
A	2006	ALL	Chassis	Power Steering Control Module																																																										
A	2006	ALL	Body	Body Control Module																																																									
A	2006	ALL	Body	Digital Radio Receiver																																																									
A	2006	ALL	Body	Instrument Panel Cluster																																																									
A	2006	ALL	Body	Radio																																																									
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2006	ALL	Body	Theft Deterrent Module																										V	V																															
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																						V																																				
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																										
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
A	2007	ALL	Chassis	Electronic Brake Control Module																																																										
A	2007	ALL	Chassis	Power Steering Control Module																																																										
A	2007	ALL	Body	Body Control Module																																																									
A	2007	ALL	Body	Digital Radio Receiver																																																									
A	2007	ALL	Body	Instrument Panel Cluster																																																									
A	2007	ALL	Body	Radio																																																									
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2007	ALL	Body	Theft Deterrent Module																										V	V																															
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module																						V																																				
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																										
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2008	HHR	Chassis	Power Steering Control Module																																																										
A	2008	HHR	Chassis	Power Steering Control Module																																																										
A	2008	HHR	Body	Body Control Module																																																									
A	2008	HHR	Body	Digital Radio Receiver																																																										
A	2008	HHR	Body	Instrument Panel Cluster																																																										
A	2008	HHR	Body	Radio																																																									
A	2008	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2008	HHR	Body	Theft Deterrent Module																										V	V																															
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module																						V																																				
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																										
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2008	HHR Panel	Body	Body Control Module																																																										
A	2008	HHR Panel	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2008	HHR Panel	Body	Radio																																																										
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2008	HHR Panel	Body	Theft Deterrent Module																									V	V																																
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																																										
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2009	HHR	Chassis	Power Steering Control Module																																																										
A	2009	HHR	Chassis	Power Steering Control Module																																																										
A	2009	HHR	Body	Body Control Module																																																										
A	2009	HHR	Body	Digital Radio Receiver																																																										
A	2009	HHR	Body	Instrument Panel Cluster																																																										
A	2009	HHR	Body	Radio																																																										
A	2009	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2009	HHR	Body	Theft Deterrent Module																									V	V																																
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2009	HHR Panel	Body	Body Control Module																																																										
A	2009	HHR Panel	Body	Digital Radio Receiver																																																										
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2009	HHR Panel	Body	Radio																																																										
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2009	HHR Panel	Body	Theft Deterrent Module																									V	V																																
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																										
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2010	HHR	Chassis	Power Steering Control Module																																																										
A	2010	HHR	Chassis	Power Steering Control Module																																																										
A	2010	HHR	Body	Body Control Module																																																										
A	2010	HHR	Body	Digital Radio Receiver																																																										
A	2010	HHR	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2010	HHR	Body	Radio																																																									
A	2010	HHR	Body	Supplemental Inflatable Restraint																																																									
A	2010	HHR	Body	Theft Deterrent Module																										V	V																															
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																									
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																									
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																									
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																									
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																									
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																									
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																									
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																									
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																									
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																									
A	2010	HHR Panel	Body	Body Control Module																																																									
A	2010	HHR Panel	Body	Digital Radio Receiver																																																									
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																									
A	2010	HHR Panel	Body	Radio																																																									
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																																									
A	2010	HHR Panel	Body	Theft Deterrent Module																										V	V																															
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																									
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																									
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																									
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																									
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																																									
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																																									
A	2011	HHR	Chassis	Power Steering Control Module																																																									
A	2011	HHR	Body	Body Control Module																																																									
A	2011	HHR	Body	Digital Radio Receiver																																																									
A	2011	HHR	Body	Instrument Panel Cluster																																																									
A	2011	HHR	Body	Radio																																																									
A	2011	HHR	Body	Supplemental Inflatable Restraint																																																									
A	2011	HHR	Body	Theft Deterrent Module																										V	V																															
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																									
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																									
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																									
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																									
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																									
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																									
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																									
A	2011	HHR Panel	Body	Body Control Module																																																									
A	2011	HHR Panel	Body	Digital Radio Receiver																																																									
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																									
A	2011	HHR Panel	Body	Radio																																																									
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																																									
A	2011	HHR Panel	Body	Theft Deterrent Module																										V	V																															
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																									
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																									
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																									
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																									
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																														
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																														
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																									
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																									
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																									
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																									
A	2013	Trax	Chassis	Electronic Brake Control Module																																																									
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2013	Trax	Chassis	Power Steering Control Module																																																									
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2013	Trax	Body	Body Control Module																																																								
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2013	Trax	Body	Passenger Presence Module																																																									
A	2013	Trax	Body	Instrument Cluster																																																								
A	2013	Trax	Body	Radio																																																								
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																								
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
A	2013	Trax	Body	Front Seat Heating Control Module																																																								
A	2013	Trax	Body	Parking Assist Control Module																																																								
A	2013	Trax	Body	Frontview Camera Module																																																								
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																								
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																																
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																										
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
A	2014	Trax	Chassis	Electronic Brake Control Module																																																										
A	2014	Trax	Chassis	Power Steering Control Module																																																										
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	Trax	Body	Body Control Module																																																									
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	Trax	Body	Passenger Presence Module																																																										
A	2014	Trax	Body	Instrument Cluster																																																									
A	2014	Trax	Body	Radio																																																									
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
A	2014	Trax	Body	Front Seat Heating Control Module																																																										
A	2014	Trax	Body	Parking Assist Control Module																																																										
A	2014	Trax	Body	Frontview Camera Module																																																										
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																															
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																															
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																										
A	2015	Trax	Powertrain	Chassis Control Module																																																										
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
A	2015	Trax	Chassis	Electronic Brake Control Module																																																										
A	2015	Trax	Chassis	Power Steering Control Module																																																										
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	Trax	Body	Body Control Module																																																									
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	Trax	Body	Passenger Presence Module																																																										
A	2015	Trax	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2015	Trax	Body	Radio																																																										
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
A	2015	Trax	Body	Seat Memory Control Module																																																										
A	2015	Trax	Body	Front Seat Heating Control Module																																																										
A	2015	Trax	Body	Right Side Object Detection Control Module																																																										
A	2015	Trax	Body	Left Side Object Detection Control Module																																																										
A	2015	Trax	Body	Parking Assist Control Module																																																										
A	2015	Trax	Body	Frontview Camera Module																																																										
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																										
A	2016	Trax	Powertrain	Chassis Control Module																																																										
A	2016	Trax	Chassis	Electronic Brake Control Module																																																										
A	2016	Trax	Chassis	Power Steering Control Module																																																										
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	Trax	Body	Body Control Module																																																									
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	Trax	Body	Passenger Presence Module																																																										
A	2016	Trax	Body	Instrument Cluster																																																									
A	2016	Trax	Body	Trailer Interface Control Module																																																										
A	2016	Trax	Body	Radio																																																										
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
A	2016	Trax	Body	Seat Memory Control Module																																																										
A	2016	Trax	Body	Front Seat Heating Control Module																																																										
A	2016	Trax	Body	Right Side Object Detection Control Module																																																										
A	2016	Trax	Body	Left Side Object Detection Control Module																																																										
A	2016	Trax	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2016	Trax	Body	Frontview Camera Module																																																									
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM											V																																														
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																														
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																														
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																														
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																														
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																														
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module										V																																															
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module											V																																														
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600											V																																														
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600											V																																														
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																														
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module										V																																															
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																									
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																															
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed											V																																														
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																									
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																									
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																									
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																									
C	2004	ALL	Chassis	Tire Pressure Monitor																																																									
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																									
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																									
C	2004	ALL	Body	Body Control Module																																																									
C	2004	ALL	Body	CD Changer																																																									
C	2004	ALL	Body	Chime																																																									
C	2004	ALL	Body	Driver Door Module																																																									
C	2004	ALL	Body	Driver Seat Module																																																									
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																									
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																									
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
C	2004	ALL	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2004	ALL	Body	OnStar																																																										
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Radio Base																																																										
C	2004	ALL	Body	Radio Uplevel																																																										
C	2004	ALL	Body	Radio Navigation																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																										
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																										
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2004	ALL	Body	Vehicle Theft Deterrent																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM											V																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																														
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																														
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module											V																																														
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																														
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module										V																																															
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600											V																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600											V																																														
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																														
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																															
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed											V																																														
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2005	ALL	Chassis	ESC																																																									
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2005	ALL	Chassis	VSES																																																										
C	2005	ALL	Body	Amplifier (Bose)																																																										
C	2005	ALL	Body	Body Control Module																																																										
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																																										
C	2005	ALL	Body	Driver Seat Module																																																										
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2005	ALL	Body	Instrument Panel Cluster																																																										
C	2005	ALL	Body	Passenger Door Module																																																										
C	2005	ALL	Body	Passenger Presence System																																																										
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio																																																										
C	2005	ALL	Body	Rear Aux. Climate Module																																																										
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2005	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM											V																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																														
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																														
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module											V																																														
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																														
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module										V																																															
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600											V																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600											V																																														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module										V																																															
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																																
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed											V																																															
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																									
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																																									
C	2006	ALL	Body	CD Changer																																																									
C	2006	ALL	Body	Chime																																																									
C	2006	ALL	Body	Disc Player and Video Display																																																									
C	2006	ALL	Body	Driver Door Module																																																									
C	2006	ALL	Body	Driver Seat Module																																																									
C	2006	ALL	Body	Generator Battery Control Module																																																									
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																									
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																									
C	2006	ALL	Body	Instrument Panel Cluster																																																									
C	2006	ALL	Body	Passenger Door Module																																																									
C	2006	ALL	Body	Passenger Presence System																																																									
C	2006	ALL	Body	Base Radio																																																									
C	2006	ALL	Body	Uplevel Radio																																																									
C	2006	ALL	Body	Navigation Radio																																																									
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																									
C	2006	ALL	Body	Rear Seat Audio																																																									
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2007	Avalanche	Body	Amplifier (Bose)																																																											
C	2007	Avalanche	Body	Assist Step Controller																																																											
C	2007	Avalanche	Body	Body Control Module																																																											
C	2007	Avalanche	Body	Body Control Module (aux.)																																																											
C	2007	Avalanche	Body	Digital Radio Receiver																																																											
C	2007	Avalanche	Body	Driver Door Switch																																																											
C	2007	Avalanche	Body	HVAC Control Module Auto																																																											
C	2007	Avalanche	Body	HVAC Control Module Manual																																																											
C	2007	Avalanche	Body	Instrument Panel Cluster																																																											
C	2007	Avalanche	Body	Memory Seat Module																																																											
C	2007	Avalanche	Body	Park Assist Module																																																											
C	2007	Avalanche	Body	Passenger Door Switch																																																											
C	2007	Avalanche	Body	Passenger Presence System																																																											
C	2007	Avalanche	Body	Radio																																																											
C	2007	Avalanche	Body	Rear Heated Seat Module																																																											
C	2007	Avalanche	Body	Rear HVAC/RSA																																																											
C	2007	Avalanche	Body	Rollover Sensor																																																											
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																											
C	2007	Avalanche	Body	Theft Deterrent Module																										V	V	V	V																														
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2007	Suburban	Chassis	Electronic Suspension Control																																																											
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																											
C	2007	Suburban	Body	Amplifier (Bose)																																																											
C	2007	Suburban	Body	Assist Step Controller																																																											
C	2007	Suburban	Body	Body Control Module																																																											
C	2007	Suburban	Body	Body Control Module (aux.)																																																											
C	2007	Suburban	Body	Digital Radio Receiver																																																											
C	2007	Suburban	Body	Driver Door Switch																																																											
C	2007	Suburban	Body	HVAC Control Module Auto																																																											
C	2007	Suburban	Body	HVAC Control Module Manual																																																											
C	2007	Suburban	Body	Instrument Panel Cluster																																																											
C	2007	Suburban	Body	Lift Gate Module																																																											
C	2007	Suburban	Body	Memory Seat Module																																																											
C	2007	Suburban	Body	Park Assist Module																																																											
C	2007	Suburban	Body	Passenger Door Switch																																																											
C	2007	Suburban	Body	Passenger Presence System																																																											
C	2007	Suburban	Body	Radio																																																											
C	2007	Suburban	Body	Rear Heated Seat Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2007	Suburban	Body	Rear HVAC/RSA																																																										
C	2007	Suburban	Body	Rollover Sensor																																																										
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2007	Suburban	Body	Theft Deterrent Module																									V	V	V	V																														
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																																
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Silverado	Chassis	Electronic Suspension Control																																																										
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																										
C	2007	Silverado	Body	Amplifier (Bose)																																																										
C	2007	Silverado	Body	Body Control Module																																																										
C	2007	Silverado	Body	Body Control Module (aux.)																																																										
C	2007	Silverado	Body	Digital Radio Receiver																																																										
C	2007	Silverado	Body	Driver Door Switch																																																										
C	2007	Silverado	Body	HVAC Control Module Auto																																																										
C	2007	Silverado	Body	HVAC Control Module Manual																																																										
C	2007	Silverado	Body	Instrument Panel Cluster																																																										
C	2007	Silverado	Body	Memory Seat Module																																																										
C	2007	Silverado	Body	Park Assist Module																																																										
C	2007	Silverado	Body	Passenger Door Switch																																																										
C	2007	Silverado	Body	Passenger Presence System																																																										
C	2007	Silverado	Body	Radio																																																										
C	2007	Silverado	Body	Rear Heated Seat Module																																																										
C	2007	Silverado	Body	Rear HVAC/RSA																																																										
C	2007	Silverado	Body	Rollover Sensor																																																										
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2007	Silverado	Body	Theft Deterrent Module																									V	V	V	V																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2007	Tahoe	Body	Amplifier (Bose)																																																										
C	2007	Tahoe	Body	Assist Step Controller																																																										
C	2007	Tahoe	Body	Body Control Module																																																										
C	2007	Tahoe	Body	Body Control Module (aux.)																																																										
C	2007	Tahoe	Body	Digital Radio Receiver																																																										
C	2007	Tahoe	Body	Driver Door Switch																																																										
C	2007	Tahoe	Body	HVAC Control Module Auto																																																										
C	2007	Tahoe	Body	HVAC Control Module Manual																																																										
C	2007	Tahoe	Body	Instrument Panel Cluster																																																										
C	2007	Tahoe	Body	Lift Gate Module																																																										
C	2007	Tahoe	Body	Memory Seat Module																																																										
C	2007	Tahoe	Body	Park Assist Module																																																										
C	2007	Tahoe	Body	Passenger Door Switch																																																										
C	2007	Tahoe	Body	Passenger Presence System																																																										
C	2007	Tahoe	Body	Radio																																																										
C	2007	Tahoe	Body	Rear Heated Seat Module																																																										
C	2007	Tahoe	Body	Rear HVAC/RSA																																																										
C	2007	Tahoe	Body	Rollover Sensor																																																										
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2007	Tahoe	Body	Theft Deterrent Module																										V	V	V	V																													
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2008	Avalanche	Body	Amplifier (Bose)																																																										
C	2008	Avalanche	Body	Assist Step Controller																																																										
C	2008	Avalanche	Body	Body Control Module																																																										
C	2008	Avalanche	Body	Body Control Module (aux.)																																																										
C	2008	Avalanche	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2008	Avalanche	Body	Driver Door Switch																																																										
C	2008	Avalanche	Body	HVAC Control Module Auto																																																										
C	2008	Avalanche	Body	HVAC Control Module Manual																																																										
C	2008	Avalanche	Body	Instrument Panel Cluster																																																										
C	2008	Avalanche	Body	Memory Seat Module																																																										
C	2008	Avalanche	Body	Park Assist Module																																																										
C	2008	Avalanche	Body	Passenger Door Switch																																																										
C	2008	Avalanche	Body	Passenger Presence System																																																										
C	2008	Avalanche	Body	Radio																																																										
C	2008	Avalanche	Body	Rear Heated Seat Module																																																										
C	2008	Avalanche	Body	Rear HVAC/RSA																																																										
C	2008	Avalanche	Body	Rollover Sensor																																																										
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2008	Avalanche	Body	Theft Deterrent Module																										V	V	V	V																													
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2008	Suburban	Chassis	Electronic Suspension Control																																																										
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																										
C	2008	Suburban	Body	Amplifier (Bose)																																																										
C	2008	Suburban	Body	Assist Step Controller																																																										
C	2008	Suburban	Body	Body Control Module																																																										
C	2008	Suburban	Body	Body Control Module (aux.)																																																										
C	2008	Suburban	Body	Digital Radio Receiver																																																										
C	2008	Suburban	Body	Driver Door Switch																																																										
C	2008	Suburban	Body	HVAC Control Module Auto																																																										
C	2008	Suburban	Body	HVAC Control Module Manual																																																										
C	2008	Suburban	Body	Instrument Panel Cluster																																																										
C	2008	Suburban	Body	Lift Gate Module																																																										
C	2008	Suburban	Body	Memory Seat Module																																																										
C	2008	Suburban	Body	Park Assist Module																																																										
C	2008	Suburban	Body	Passenger Door Switch																																																										
C	2008	Suburban	Body	Passenger Presence System																																																										
C	2008	Suburban	Body	Radio																																																										
C	2008	Suburban	Body	Rear Heated Seat Module																																																										
C	2008	Suburban	Body	Rear HVAC/RSA																																																										
C	2008	Suburban	Body	Rollover Sensor																																																										
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2008	Suburban	Body	Theft Deterrent Module																										V	V	V	V																													
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																																
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2008	Silverado	Chassis	Electronic Suspension Control																																																										
C	2008	Silverado	Chassis	Trailer Brake Control Module																																																										
C	2008	Silverado	Body	Amplifier (Bose)																																																										
C	2008	Silverado	Body	Body Control Module																																																										
C	2008	Silverado	Body	Body Control Module (aux.)																																																										
C	2008	Silverado	Body	Digital Radio Receiver																																																										
C	2008	Silverado	Body	Driver Door Switch																																																										
C	2008	Silverado	Body	HVAC Control Module Auto																																																										
C	2008	Silverado	Body	HVAC Control Module Manual																																																										
C	2008	Silverado	Body	Instrument Panel Cluster																																																										
C	2008	Silverado	Body	Memory Seat Module																																																										
C	2008	Silverado	Body	Park Assist Module																																																										
C	2008	Silverado	Body	Passenger Door Switch																																																										
C	2008	Silverado	Body	Passenger Presence System																																																										
C	2008	Silverado	Body	Radio																																																										
C	2008	Silverado	Body	Rear Heated Seat Module																																																										
C	2008	Silverado	Body	Rear HVAC/RSA																																																										
C	2008	Silverado	Body	Rollover Sensor																																																										
C	2008	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2008	Silverado	Body	Theft Deterrent Module																										V	V	V	V																													
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																																										
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2008	Tahoe	Body	Amplifier (Bose)																																																										
C	2008	Tahoe	Body	Assist Step Controller																																																										
C	2008	Tahoe	Body	Body Control Module																																																										
C	2008	Tahoe	Body	Body Control Module (aux.)																																																										
C	2008	Tahoe	Body	Digital Radio Receiver																																																										
C	2008	Tahoe	Body	Driver Door Switch																																																										
C	2008	Tahoe	Body	HVAC Control Module Auto																																																										
C	2008	Tahoe	Body	HVAC Control Module Manual																																																										
C	2008	Tahoe	Body	Instrument Panel Cluster																																																										
C	2008	Tahoe	Body	Memory Seat Module																																																										
C	2008	Tahoe	Body	Park Assist Module																																																										
C	2008	Tahoe	Body	Passenger Presence System																																																										
C	2008	Tahoe	Body	Radio																																																										
C	2008	Tahoe	Body	Rear Heated Seat Module																																																										
C	2008	Tahoe	Body	Rear HVAC/RSA																																																										
C	2008	Tahoe	Body	Rollover Sensor																																																										
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2008	Tahoe	Body	Theft Deterrent Module																										V	V	V	V																													
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2008	Tahoe Hybrid	Body	Body Control Module																																																										
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2008	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2008	Tahoe Hybrid	Body	Memory Seat Module																																																										
C	2008	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2008	Tahoe Hybrid	Body	Radio																																																								
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																																								
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module																										V	V	V	V																											
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																								
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
C	2009	Avalanche	Chassis	Electronic Brake Control Module																																																								
C	2009	Avalanche	Chassis	Electronic Suspension Control																																																								
C	2009	Avalanche	Chassis	Trailer Brake Control Module																																																								
C	2009	Avalanche	Body	Amplifier (Bose)																																																								
C	2009	Avalanche	Body	Assist Step Controller																																																								
C	2009	Avalanche	Body	Body Control Module																																																								
C	2009	Avalanche	Body	Body Control Module (aux.)																																																								
C	2009	Avalanche	Body	Digital Radio Receiver																																																								
C	2009	Avalanche	Body	Driver Door Switch																																																								
C	2009	Avalanche	Body	HVAC Control Module Auto																																																								
C	2009	Avalanche	Body	HVAC Control Module Manual																																																								
C	2009	Avalanche	Body	Instrument Panel Cluster																																																								
C	2009	Avalanche	Body	Memory Seat Module																																																								
C	2009	Avalanche	Body	Park Assist Module																																																								
C	2009	Avalanche	Body	Passenger Door Switch																																																								
C	2009	Avalanche	Body	Passenger Presence System																																																								
C	2009	Avalanche	Body	Radio																																																								
C	2009	Avalanche	Body	Rear Heated Seat Module																																																								
C	2009	Avalanche	Body	Rear HVAC/RSA																																																								
C	2009	Avalanche	Body	Rollover Sensor																																																								
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																								
C	2009	Avalanche	Body	Theft Deterrent Module																										V	V	V	V																											
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																										
C	2009	Cheyenne	Body	Amplifier (Bose)																																																										
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2009	Cheyenne	Body	Digital Radio Receiver																																																										
C	2009	Cheyenne	Body	Driver Door Switch																																																										
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2009	Cheyenne	Body	Park Assist Module																																																										
C	2009	Cheyenne	Body	Passenger Door Switch																																																										
C	2009	Cheyenne	Body	Passenger Presence System																																																										
C	2009	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2009	Cheyenne	Body	Rollover Sensor																																																										
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2009	Cheyenne	Body	Theft Deterrent Module																										V	V	V	V																													
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2009	Suburban	Chassis	Electronic Suspension Control																																																										
C	2009	Suburban	Chassis	Trailer Brake Control Module																																																										
C	2009	Suburban	Body	Amplifier (Bose)																																																										
C	2009	Suburban	Body	Assist Step Controller																																																										
C	2009	Suburban	Body	Body Control Module																																																										
C	2009	Suburban	Body	Body Control Module (aux.)																																																										
C	2009	Suburban	Body	Digital Radio Receiver																																																										
C	2009	Suburban	Body	Driver Door Switch																																																										
C	2009	Suburban	Body	HVAC Control Module Auto																																																										
C	2009	Suburban	Body	HVAC Control Module Manual																																																										
C	2009	Suburban	Body	Instrument Panel Cluster																																																										
C	2009	Suburban	Body	Left Side Object Detection Module																																																										
C	2009	Suburban	Body	Lift Gate Module																																																										
C	2009	Suburban	Body	Memory Seat Module																																																										
C	2009	Suburban	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2009	Suburban	Body	Passenger Door Switch																																																									
C	2009	Suburban	Body	Passenger Presence System																																																									
C	2009	Suburban	Body	Radio																																																									
C	2009	Suburban	Body	Rear Heated Seat Module																																																									
C	2009	Suburban	Body	Rear HVAC/RSA																																																									
C	2009	Suburban	Body	Right Side Object Detection Module																																																									
C	2009	Suburban	Body	Rollover Sensor																																																									
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																																									
C	2009	Suburban	Body	Theft Deterrent Module																										V	V	V	V																												
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																									
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																									
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																									
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																									
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																									
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																									
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
C	2009	Silverado	Chassis	Electronic Suspension Control																																																									
C	2009	Silverado	Chassis	Trailer Brake Control Module																																																									
C	2009	Silverado	Body	Amplifier (Bose)																																																									
C	2009	Silverado	Body	Body Control Module																																																									
C	2009	Silverado	Body	Body Control Module (aux.)																																																									
C	2009	Silverado	Body	Digital Radio Receiver																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2009	Silverado	Body	Driver Door Switch																																																									
C	2009	Silverado	Body	HVAC Control Module Auto																																																									
C	2009	Silverado	Body	HVAC Control Module Manual																																																									
C	2009	Silverado	Body	Instrument Panel Cluster																																																									
C	2009	Silverado	Body	Memory Seat Module																																																									
C	2009	Silverado	Body	Park Assist Module																																																									
C	2009	Silverado	Body	Passenger Door Switch																																																									
C	2009	Silverado	Body	Passenger Presence System																																																									
C	2009	Silverado	Body	Radio																																																									
C	2009	Silverado	Body	Rear Heated Seat Module																																																									
C	2009	Silverado	Body	Rear HVAC/RSA																																																									
C	2009	Silverado	Body	Rollover Sensor																																																									
C	2009	Silverado	Body	Supplemental Inflatable Restraint																																																									
C	2009	Silverado	Body	Theft Deterrent Module																										V	V	V	V																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																									
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																															V										
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																									
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																									
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																									
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																									
C	2009	Silverado Hybrid	Body	Body Control Module																																																									
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																									
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																									
C	2009	Silverado Hybrid	Body	Driver Door Switch																																																									
C	2009	Silverado Hybrid	Body	HVAC Control Module																																																									
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																									
C	2009	Silverado Hybrid	Body	Memory Seat Module																																																									
C	2009	Silverado Hybrid	Body	Park Assist Module																																																									
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																																									
C	2009	Silverado Hybrid	Body	Passenger Presence System																																																									
C	2009	Silverado Hybrid	Body	Radio																																																									
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																									
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																									
C	2009	Silverado Hybrid	Body	Rollover Sensor																																																									
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																									
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																									
C	2009	Silverado Hybrid	Body	Theft Deterrent Module																										V	V	V	V																												
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2009	Tahoe	Body	Amplifier (Bose)																																																										
C	2009	Tahoe	Body	Assist Step Controller																																																										
C	2009	Tahoe	Body	Body Control Module																																																										
C	2009	Tahoe	Body	Body Control Module (aux.)																																																										
C	2009	Tahoe	Body	Digital Radio Receiver																																																										
C	2009	Tahoe	Body	Driver Door Switch																																																										
C	2009	Tahoe	Body	HVAC Control Module Auto																																																										
C	2009	Tahoe	Body	HVAC Control Module Manual																																																										
C	2009	Tahoe	Body	Instrument Panel Cluster																																																										
C	2009	Tahoe	Body	Left Side Object Detection Module																																																										
C	2009	Tahoe	Body	Lift Gate Module																																																										
C	2009	Tahoe	Body	Memory Seat Module																																																										
C	2009	Tahoe	Body	Park Assist Module																																																										
C	2009	Tahoe	Body	Passenger Door Switch																																																										
C	2009	Tahoe	Body	Passenger Presence System																																																										
C	2009	Tahoe	Body	Radio																																																										
C	2009	Tahoe	Body	Rear Heated Seat Module																																																										
C	2009	Tahoe	Body	Rear HVAC/RSA																																																										
C	2009	Tahoe	Body	Right Side Object Detection Module																																																										
C	2009	Tahoe	Body	Rollover Sensor																																																										
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2009	Tahoe	Body	Theft Deterrent Module																										V	V	V	V																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2009	Tahoe Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																																								
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																																								
C	2009	Tahoe Hybrid	Body	HVAC Control Module																																																								
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
C	2009	Tahoe Hybrid	Body	Park Assist Module																																																								
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																								
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																																								
C	2009	Tahoe Hybrid	Body	Radio																																																								
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																								
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																										V	V	V	V																											
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2010	Avalanche	Chassis	Electronic Brake Control Module																																																								
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																								
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Avalanche	Body	Amplifier (Bose)																																																								
C	2010	Avalanche	Body	Assist Step Controller																																																								
C	2010	Avalanche	Body	Body Control Module																																																								
C	2010	Avalanche	Body	Body Control Module (aux.)																																																								
C	2010	Avalanche	Body	Digital Radio Receiver																																																								
C	2010	Avalanche	Body	Driver Door Switch																																																								
C	2010	Avalanche	Body	HVAC Control Module Auto																																																								
C	2010	Avalanche	Body	HVAC Control Module Manual																																																								
C	2010	Avalanche	Body	Instrument Panel Cluster																																																								
C	2010	Avalanche	Body	Memory Seat Module																																																								
C	2010	Avalanche	Body	Park Assist Module																																																								
C	2010	Avalanche	Body	Passenger Door Switch																																																								
C	2010	Avalanche	Body	Passenger Presence System																																																								
C	2010	Avalanche	Body	Radio																																																								
C	2010	Avalanche	Body	Rear Heated Seat Module																																																								
C	2010	Avalanche	Body	Rear HVAC/RSA																																																								
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																								
C	2010	Avalanche	Body	Theft Deterrent Module																										V	V	V	V																											
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Cheyenne	Body	Amplifier (Bose)																																																										
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2010	Cheyenne	Body	Digital Radio Receiver																																																										
C	2010	Cheyenne	Body	Driver Door Switch																																																										
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2010	Cheyenne	Body	Park Assist Module																																																										
C	2010	Cheyenne	Body	Passenger Door Switch																																																										
C	2010	Cheyenne	Body	Passenger Presence System																																																										
C	2010	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2010	Cheyenne	Body	Theft Deterrent Module																										V	V	V	V																													
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2010	Suburban	Chassis	Electronic Suspension Control																																																										
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Suburban	Body	Amplifier (Bose)																																																										
C	2010	Suburban	Body	Assist Step Controller																																																										
C	2010	Suburban	Body	Body Control Module																																																										
C	2010	Suburban	Body	Body Control Module (aux.)																																																										
C	2010	Suburban	Body	Digital Radio Receiver																																																										
C	2010	Suburban	Body	Driver Door Switch																																																										
C	2010	Suburban	Body	HVAC Control Module Auto																																																										
C	2010	Suburban	Body	HVAC Control Module Manual																																																										
C	2010	Suburban	Body	Instrument Panel Cluster																																																										
C	2010	Suburban	Body	Left Side Object Detection Module																																																										
C	2010	Suburban	Body	Lift Gate Module																																																										
C	2010	Suburban	Body	Memory Seat Module																																																										
C	2010	Suburban	Body	Park Assist Module																																																										
C	2010	Suburban	Body	Passenger Door Switch																																																										
C	2010	Suburban	Body	Passenger Presence System																																																										
C	2010	Suburban	Body	Radio																																																										
C	2010	Suburban	Body	Rear Heated Seat Module																																																										
C	2010	Suburban	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2010	Suburban	Body	Right Side Object Detection Module																																																										
C	2010	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2010	Suburban	Body	Theft Deterrent Module																									V	V	V	V																														
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																										
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2010	Silverado	Chassis	Electronic Suspension Control																																																										
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2010	Silverado	Body	Amplifier (Bose)																																																										
C	2010	Silverado	Body	Body Control Module																																																									
C	2010	Silverado	Body	Body Control Module (aux.)																																																										
C	2010	Silverado	Body	Digital Radio Receiver																																																										
C	2010	Silverado	Body	Driver Door Switch																																																										
C	2010	Silverado	Body	HVAC Control Module Auto																																																										
C	2010	Silverado	Body	HVAC Control Module Manual																																																										
C	2010	Silverado	Body	Instrument Panel Cluster																																																										
C	2010	Silverado	Body	Memory Seat Module																																																										
C	2010	Silverado	Body	Park Assist Module																																																										
C	2010	Silverado	Body	Passenger Door Switch																																																										
C	2010	Silverado	Body	Passenger Presence System																																																										
C	2010	Silverado	Body	Radio																																																										
C	2010	Silverado	Body	Rear Heated Seat Module																																																										
C	2010	Silverado	Body	Rear HVAC/RSA																																																										
C	2010	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2010	Silverado	Body	Theft Deterrent Module																									V	V	V	V																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										V
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2010	Silverado Hybrid	Body	Body Control Module																																																										
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2010	Silverado Hybrid	Body	HVAC Control Module																																																										
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2010	Silverado Hybrid	Body	Park Assist Module																																																										
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2010	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2010	Silverado Hybrid	Body	Radio																																																										
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Tahoe	Body	Amplifier (Bose)																																																										
C	2010	Tahoe	Body	Assist Step Controller																																																										
C	2010	Tahoe	Body	Body Control Module																																																										
C	2010	Tahoe	Body	Body Control Module (aux.)																																																										
C	2010	Tahoe	Body	Digital Radio Receiver																																																										
C	2010	Tahoe	Body	Driver Door Switch																																																										
C	2010	Tahoe	Body	HVAC Control Module Auto																																																										
C	2010	Tahoe	Body	HVAC Control Module Manual																																																										
C	2010	Tahoe	Body	Instrument Panel Cluster																																																										
C	2010	Tahoe	Body	Left Side Object Detection Module																																																										
C	2010	Tahoe	Body	Lift Gate Module																																																										
C	2010	Tahoe	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2010	Tahoe	Body	Park Assist Module																																																									
C	2010	Tahoe	Body	Passenger Door Switch																																																									
C	2010	Tahoe	Body	Passenger Presence System																																																									
C	2010	Tahoe	Body	Radio																																																									
C	2010	Tahoe	Body	Rear Heated Seat Module																																																									
C	2010	Tahoe	Body	Rear HVAC/RSA																																																									
C	2010	Tahoe	Body	Right Side Object Detection Module																																																									
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																									
C	2010	Tahoe	Body	Theft Deterrent Module																									V	V	V	V																													
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																									
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																														V											
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
C	2010	Tahoe Hybrid	Body	Body Control Module																																																									
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																																									
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																																									
C	2010	Tahoe Hybrid	Body	HVAC Control Module																																																									
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																									
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																																									
C	2010	Tahoe Hybrid	Body	Park Assist Module																																																									
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																									
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																																									
C	2010	Tahoe Hybrid	Body	Radio																																																									
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																									
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																									
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																									
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																									V	V	V	V																													
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2011	Avalanche	Chassis	Electronic Brake Control Module																																																									
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																									
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2011	Avalanche	Body	Amplifier (Bose)																																																										
C	2011	Avalanche	Body	Assist Step Controller																																																										
C	2011	Avalanche	Body	Body Control Module																																																										
C	2011	Avalanche	Body	Body Control Module (aux.)																																																										
C	2011	Avalanche	Body	Digital Radio Receiver																																																										
C	2011	Avalanche	Body	Driver Door Switch																																																										
C	2011	Avalanche	Body	HVAC Control Module Auto																																																										
C	2011	Avalanche	Body	HVAC Control Module Manual																																																										
C	2011	Avalanche	Body	Instrument Panel Cluster																																																										
C	2011	Avalanche	Body	Memory Seat Module																																																										
C	2011	Avalanche	Body	Park Assist Module																																																										
C	2011	Avalanche	Body	Passenger Door Switch																																																										
C	2011	Avalanche	Body	Passenger Presence System																																																										
C	2011	Avalanche	Body	Radio																																																										
C	2011	Avalanche	Body	Rear Heated Seat Module																																																										
C	2011	Avalanche	Body	Rear HVAC/RSA																																																										
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2011	Avalanche	Body	Theft Deterrent Module																										V	V	V	V																														
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2011	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2011	Captiva	Chassis	Parking Brake Control Module																																																										
C	2011	Captiva	Body	Body Control Module																																																										
C	2011	Captiva	Body	Auxiliary Body Control Module																																																										
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2011	Captiva	Body	Instrument Cluster																																																										
C	2011	Captiva	Body	Headlamp Control Module																																																										
C	2011	Captiva	Body	HVAC Control Module																																																										
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																										
C	2011	Captiva	Body	Parking Assist Control Module																																																										
C	2011	Captiva	Body	Theft Deterrent Module				V	V																																																					
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																										
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Cheyenne	Body	Amplifier (Bose)																																																										
C	2011	Cheyenne	Body	Body Control Module																																																										
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2011	Cheyenne	Body	Digital Radio Receiver																																																										
C	2011	Cheyenne	Body	Driver Door Switch																																																										
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2011	Cheyenne	Body	Park Assist Module																																																										
C	2011	Cheyenne	Body	Passenger Door Switch																																																										
C	2011	Cheyenne	Body	Passenger Presence System																																																										
C	2011	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2011	Cheyenne	Body	Theft Deterrent Module																										V	V	V	V																													
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2011	Suburban	Chassis	Electronic Suspension Control																																																										
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Suburban	Body	Amplifier (Bose)																																																										
C	2011	Suburban	Body	Assist Step Controller																																																										
C	2011	Suburban	Body	Body Control Module																																																										
C	2011	Suburban	Body	Body Control Module (aux.)																																																										
C	2011	Suburban	Body	Digital Radio Receiver																																																										
C	2011	Suburban	Body	Driver Door Switch																																																										
C	2011	Suburban	Body	HVAC Control Module Auto																																																										
C	2011	Suburban	Body	HVAC Control Module Manual																																																										
C	2011	Suburban	Body	Instrument Panel Cluster																																																										
C	2011	Suburban	Body	Left Side Object Detection Module																																																										
C	2011	Suburban	Body	Lift Gate Module																																																										
C	2011	Suburban	Body	Memory Seat Module																																																										
C	2011	Suburban	Body	Park Assist Module																																																										
C	2011	Suburban	Body	Passenger Door Switch																																																										
C	2011	Suburban	Body	Passenger Presence System																																																										
C	2011	Suburban	Body	Radio																																																										
C	2011	Suburban	Body	Rear Heated Seat Module																																																										
C	2011	Suburban	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2011	Suburban	Body	Right Side Object Detection Module																																																										
C	2011	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2011	Suburban	Body	Theft Deterrent Module																									V	V	V	V																														
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																										
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module										V																																																
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																																
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2011	Silverado	Chassis	Electronic Suspension Control																																																										
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2011	Silverado	Body	Amplifier (Bose)																																																										
C	2011	Silverado	Body	Body Control Module																																																										
C	2011	Silverado	Body	Body Control Module (aux.)																																																										
C	2011	Silverado	Body	Digital Radio Receiver																																																										
C	2011	Silverado	Body	Driver Door Switch																																																										
C	2011	Silverado	Body	HVAC Control Module Auto																																																										
C	2011	Silverado	Body	HVAC Control Module Manual																																																										
C	2011	Silverado	Body	Instrument Panel Cluster																																																										
C	2011	Silverado	Body	Memory Seat Module																																																										
C	2011	Silverado	Body	Park Assist Module																																																										
C	2011	Silverado	Body	Passenger Door Switch																																																										
C	2011	Silverado	Body	Passenger Presence System																																																										
C	2011	Silverado	Body	Radio																																																										
C	2011	Silverado	Body	Rear Heated Seat Module																																																										
C	2011	Silverado	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																																									
C	2011	Silverado	Body	Theft Deterrent Module																										V	V	V	V																												
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Silverado Hybrid	Body	Body Control Module																																																										
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2011	Silverado Hybrid	Body	HVAC Control Module																																																										
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Silverado Hybrid	Body	Park Assist Module																																																										
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2011	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2011	Silverado Hybrid	Body	Radio																																																										
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																										V	V	V	V																												
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe	Body	Amplifier (Bose)																																																										
C	2011	Tahoe	Body	Assist Step Controller																																																										
C	2011	Tahoe	Body	Body Control Module																																																										
C	2011	Tahoe	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe	Body	Digital Radio Receiver																																																										
C	2011	Tahoe	Body	Driver Door Switch																																																										
C	2011	Tahoe	Body	HVAC Control Module Auto																																																										
C	2011	Tahoe	Body	HVAC Control Module Manual																																																										
C	2011	Tahoe	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe	Body	Left Side Object Detection Module																																																										
C	2011	Tahoe	Body	Lift Gate Module																																																										
C	2011	Tahoe	Body	Memory Seat Module																																																										
C	2011	Tahoe	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2011	Tahoe	Body	Passenger Door Switch																																																										
C	2011	Tahoe	Body	Passenger Presence System																																																										
C	2011	Tahoe	Body	Radio																																																										
C	2011	Tahoe	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe	Body	Right Side Object Detection Module																																																										
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2011	Tahoe	Body	Theft Deterrent Module																										V	V	V	V																														
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2011	Tahoe Hybrid	Body	Body Control Module																																																											
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																																											
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																																											
C	2011	Tahoe Hybrid	Body	HVAC Control Module																																																											
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																																											
C	2011	Tahoe Hybrid	Body	Park Assist Module																																																											
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																											
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																																											
C	2011	Tahoe Hybrid	Body	Radio																																																											
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																										V	V	V	V																														
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2012	Avalanche	Chassis	Electronic Brake Control Module																																																											
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																											
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2012	Avalanche	Body	Amplifier (Bose)																																																										
C	2012	Avalanche	Body	Assist Step Controller																																																										
C	2012	Avalanche	Body	Body Control Module																																																										
C	2012	Avalanche	Body	Body Control Module (aux.)																																																										
C	2012	Avalanche	Body	Digital Radio Receiver																																																										
C	2012	Avalanche	Body	Driver Door Switch																																																										
C	2012	Avalanche	Body	HVAC Control Module Auto																																																										
C	2012	Avalanche	Body	HVAC Control Module Manual																																																										
C	2012	Avalanche	Body	Instrument Panel Cluster																																																										
C	2012	Avalanche	Body	Memory Seat Module																																																										
C	2012	Avalanche	Body	Navigation Radio																																																										
C	2012	Avalanche	Body	Park Assist Module																																																										
C	2012	Avalanche	Body	Passenger Door Switch																																																										
C	2012	Avalanche	Body	Passenger Presence System																																																										
C	2012	Avalanche	Body	Radio																																																										
C	2012	Avalanche	Body	Rear Heated Seat Module																																																										
C	2012	Avalanche	Body	Rear HVAC/RSA																																																										
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2012	Avalanche	Body	Theft Deterrent Module																										V	V	V	V																													
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2012	Captiva	Chassis	Parking Brake Control Module																																																										
C	2012	Captiva	Body	Body Control Module																																																										
C	2012	Captiva	Body	Auxiliary Body Control Module																																																										
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2012	Captiva	Body	Instrument Cluster																																																										
C	2012	Captiva	Body	Headlamp Control Module																																																										
C	2012	Captiva	Body	HVAC Control Module																																																										
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																										
C	2012	Captiva	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2012	Captiva	Body	Theft Deterrent Module				V	V																																																				
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																									
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																									
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																									
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																									
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																									
C	2012	Cheyenne	Body	Amplifier (Bose)																																																									
C	2012	Cheyenne	Body	Body Control Module																																																									
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																									
C	2012	Cheyenne	Body	Digital Radio Receiver																																																									
C	2012	Cheyenne	Body	Driver Door Switch																																																									
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																									
C	2012	Cheyenne	Body	Park Assist Module																																																									
C	2012	Cheyenne	Body	Passenger Door Switch																																																									
C	2012	Cheyenne	Body	Passenger Presence System																																																									
C	2012	Cheyenne	Body	Rear Heated Seat Module																																																									
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																									
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																									
C	2012	Cheyenne	Body	Theft Deterrent Module																										V	V	V	V																												
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																									
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
C	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																									
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2012	Suburban	Chassis	Electronic Suspension Control																																																									
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2012	Suburban	Body	Amplifier (Bose)																																																									
C	2012	Suburban	Body	Assist Step Controller																																																									
C	2012	Suburban	Body	Body Control Module																																																									
C	2012	Suburban	Body	Body Control Module (aux.)																																																									
C	2012	Suburban	Body	Digital Radio Receiver																																																									
C	2012	Suburban	Body	Driver Door Switch																																																									
C	2012	Suburban	Body	HVAC Control Module Auto																																																									
C	2012	Suburban	Body	HVAC Control Module Manual																																																									
C	2012	Suburban	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2012	Suburban	Body	Left Side Object Detection Module																																																										
C	2012	Suburban	Body	Lift Gate Module																																																										
C	2012	Suburban	Body	Memory Seat Module																																																										
C	2012	Suburban	Body	Navigation Radio																																																										
C	2012	Suburban	Body	Park Assist Module																																																										
C	2012	Suburban	Body	Passenger Door Switch																																																										
C	2012	Suburban	Body	Passenger Presence System																																																										
C	2012	Suburban	Body	Radio																																																										
C	2012	Suburban	Body	Rear Heated Seat Module																																																										
C	2012	Suburban	Body	Rear HVAC/RSA																																																										
C	2012	Suburban	Body	Right Side Object Detection Module																																																										
C	2012	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2012	Suburban	Body	Theft Deterrent Module																									V	V	V	V																														
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																										
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module										V																																															
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2012	Silverado	Chassis	Electronic Suspension Control																																																										
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2012	Silverado	Body	Amplifier (Bose)																																																										
C	2012	Silverado	Body	Body Control Module																																																										
C	2012	Silverado	Body	Body Control Module (aux.)																																																										
C	2012	Silverado	Body	Digital Radio Receiver																																																										
C	2012	Silverado	Body	Driver Door Switch																																																										
C	2012	Silverado	Body	HVAC Control Module Auto																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2012	Silverado	Body	HVAC Control Module Manual																																																									
C	2012	Silverado	Body	Instrument Panel Cluster																																																									
C	2012	Silverado	Body	Memory Seat Module																																																									
C	2012	Silverado	Body	Navigation Radio																																																									
C	2012	Silverado	Body	Park Assist Module																																																									
C	2012	Silverado	Body	Passenger Door Switch																																																									
C	2012	Silverado	Body	Passenger Presence System																																																									
C	2012	Silverado	Body	Radio																																																									
C	2012	Silverado	Body	Rear Heated Seat Module																																																									
C	2012	Silverado	Body	Rear HVAC/RSA																																																									
C	2012	Silverado	Body	Supplemental Inflatable Restraint																																																									
C	2012	Silverado	Body	Theft Deterrent Module																										V	V	V	V																												
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																									
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																														V											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																									
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																									
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																									
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																									
C	2012	Silverado Hybrid	Body	Body Control Module																																																									
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																									
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																									
C	2012	Silverado Hybrid	Body	Driver Door Switch																																																									
C	2012	Silverado Hybrid	Body	Heated Seat Module																																																									
C	2012	Silverado Hybrid	Body	HVAC Control Module																																																									
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																									
C	2012	Silverado Hybrid	Body	Navigation Radio																																																									
C	2012	Silverado Hybrid	Body	Park Assist Module																																																									
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																																									
C	2012	Silverado Hybrid	Body	Passenger Presence System																																																									
C	2012	Silverado Hybrid	Body	Radio																																																									
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																									
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																									
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																									
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																									
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																										V	V	V	V																												
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2012	Tahoe	Chassis	Electronic Brake Control Module																																																									
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																									
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
C	2012	Tahoe	Body	Amplifier (Bose)																																																									
C	2012	Tahoe	Body	Assist Step Controller																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2012	Tahoe	Body	Body Control Module																																																									
C	2012	Tahoe	Body	Body Control Module (aux.)																																																									
C	2012	Tahoe	Body	Digital Radio Receiver																																																									
C	2012	Tahoe	Body	Driver Door Switch																																																									
C	2012	Tahoe	Body	HVAC Control Module Auto																																																									
C	2012	Tahoe	Body	HVAC Control Module Manual																																																									
C	2012	Tahoe	Body	Instrument Panel Cluster																																																									
C	2012	Tahoe	Body	Left Side Object Detection Module																																																									
C	2012	Tahoe	Body	Lift Gate Module																																																									
C	2012	Tahoe	Body	Memory Seat Module																																																									
C	2012	Tahoe	Body	Navigation Radio																																																									
C	2012	Tahoe	Body	Park Assist Module																																																									
C	2012	Tahoe	Body	Passenger Door Switch																																																									
C	2012	Tahoe	Body	Passenger Presence System																																																									
C	2012	Tahoe	Body	Radio																																																									
C	2012	Tahoe	Body	Rear Heated Seat Module																																																									
C	2012	Tahoe	Body	Rear HVAC/RSA																																																									
C	2012	Tahoe	Body	Right Side Object Detection Module																																																									
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																									
C	2012	Tahoe	Body	Theft Deterrent Module																										V	V	V	V																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																									
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																													V												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
C	2012	Tahoe Hybrid	Body	Body Control Module																																																									
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																																									
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																																									
C	2012	Tahoe Hybrid	Body	HVAC Control Module																																																									
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																									
C	2012	Tahoe Hybrid	Body	Lift Gate Module																																																									
C	2012	Tahoe Hybrid	Body	Navigation Radio																																																									
C	2012	Tahoe Hybrid	Body	Park Assist Module																																																									
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																									
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																																									
C	2012	Tahoe Hybrid	Body	Radio																																																									
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																									
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																									V	V	V	V																														
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Avalanche	Body	Amplifier (Bose)																																																										
C	2013	Avalanche	Body	Assist Step Controller																																																										
C	2013	Avalanche	Body	Body Control Module																																																										
C	2013	Avalanche	Body	Body Control Module (aux.)																																																										
C	2013	Avalanche	Body	Digital Radio Receiver																																																										
C	2013	Avalanche	Body	Driver Door Switch																																																										
C	2013	Avalanche	Body	HVAC Control Module Auto																																																										
C	2013	Avalanche	Body	HVAC Control Module Manual																																																										
C	2013	Avalanche	Body	Instrument Panel Cluster																																																										
C	2013	Avalanche	Body	Memory Seat Module																																																										
C	2013	Avalanche	Body	Navigation Radio																																																										
C	2013	Avalanche	Body	Park Assist Module																																																										
C	2013	Avalanche	Body	Passenger Door Switch																																																										
C	2013	Avalanche	Body	Passenger Presence System																																																										
C	2013	Avalanche	Body	Radio																																																										
C	2013	Avalanche	Body	Rear Heated Seat Module																																																										
C	2013	Avalanche	Body	Rear HVAC/RSA																																																										
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2013	Avalanche	Body	Theft Deterrent Module																									V	V	V	V																														
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2013	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2013	Captiva	Chassis	Parking Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																										
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																										
C	2013	Captiva	Body	Auxiliary Body Control Module																																																										
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2013	Captiva	Body	Instrument Cluster																																																										
C	2013	Captiva	Body	Headlamp Control Module																																																										
C	2013	Captiva	Body	HVAC Control Module																																																										
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)				V	V	V	V																																																			
C	2013	Captiva	Body	Theft Deterrent Module				V	V																																																						
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																										
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Cheyenne	Body	Amplifier (Bose)																																																										
C	2013	Cheyenne	Body	Body Control Module																																																										
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2013	Cheyenne	Body	Digital Radio Receiver																																																										
C	2013	Cheyenne	Body	Driver Door Switch																																																										
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2013	Cheyenne	Body	Park Assist Module																																																										
C	2013	Cheyenne	Body	Passenger Door Switch																																																										
C	2013	Cheyenne	Body	Passenger Presence System																																																										
C	2013	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2013	Cheyenne	Body	Theft Deterrent Module																										V	V	V	V																													
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																										
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2013	Suburban	Chassis	Electronic Suspension Control																																																										
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Suburban	Body	Amplifier (Bose)																																																											
C	2013	Suburban	Body	Assist Step Controller																																																											
C	2013	Suburban	Body	Body Control Module																																																											
C	2013	Suburban	Body	Body Control Module (aux.)																																																											
C	2013	Suburban	Body	Digital Radio Receiver																																																											
C	2013	Suburban	Body	Driver Door Switch																																																											
C	2013	Suburban	Body	HVAC Control Module Auto																																																											
C	2013	Suburban	Body	HVAC Control Module Manual																																																											
C	2013	Suburban	Body	Instrument Panel Cluster																																																											
C	2013	Suburban	Body	Left Side Object Detection Module																																																											
C	2013	Suburban	Body	Lift Gate Module																																																											
C	2013	Suburban	Body	Memory Seat Module																																																											
C	2013	Suburban	Body	Navigation Radio																																																											
C	2013	Suburban	Body	Park Assist Module																																																											
C	2013	Suburban	Body	Passenger Door Switch																																																											
C	2013	Suburban	Body	Passenger Presence System																																																											
C	2013	Suburban	Body	Radio																																																											
C	2013	Suburban	Body	Rear Heated Seat Module																																																											
C	2013	Suburban	Body	Rear HVAC/RSA																																																											
C	2013	Suburban	Body	Right Side Object Detection Module																																																											
C	2013	Suburban	Body	Supplemental Inflatable Restraint																																																											
C	2013	Suburban	Body	Theft Deterrent Module																										V	V	V	V																														
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																											
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																											
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																											
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module										V																																																
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																											
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2013	Silverado	Chassis	Electronic Suspension Control																																																											
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2013	Silverado	Body	Amplifier (Bose)																																																											
C	2013	Silverado	Body	Body Control Module																																																											
C	2013	Silverado	Body	Body Control Module (aux.)																																																											
C	2013	Silverado	Body	Digital Radio Receiver																																																											
C	2013	Silverado	Body	Driver Door Switch																																																											
C	2013	Silverado	Body	HVAC Control Module Auto																																																											
C	2013	Silverado	Body	HVAC Control Module Manual																																																											
C	2013	Silverado	Body	Instrument Panel Cluster																																																											
C	2013	Silverado	Body	Memory Seat Module																																																											
C	2013	Silverado	Body	Navigation Radio																																																											
C	2013	Silverado	Body	Park Assist Module																																																											
C	2013	Silverado	Body	Passenger Door Switch																																																											
C	2013	Silverado	Body	Passenger Presence System																																																											
C	2013	Silverado	Body	Radio																																																											
C	2013	Silverado	Body	Rear Heated Seat Module																																																											
C	2013	Silverado	Body	Rear HVAC/RSA																																																											
C	2013	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2013	Silverado	Body	Theft Deterrent Module																										V	V	V	V																														
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																											
C	2013	Silverado Hybrid	Body	Body Control Module																																																											
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																											
C	2013	Silverado Hybrid	Body	Driver Door Switch																																																											
C	2013	Silverado Hybrid	Body	Heated Seat Module																																																											
C	2013	Silverado Hybrid	Body	HVAC Control Module																																																											
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
C	2013	Silverado Hybrid	Body	Navigation Radio																																																											
C	2013	Silverado Hybrid	Body	Park Assist Module																																																											
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2013	Silverado Hybrid	Body	Passenger Presence System																																																											
C	2013	Silverado Hybrid	Body	Radio																																																											
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																									V	V	V	V																															
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2013	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe	Body	Amplifier (Bose)																																																											
C	2013	Tahoe	Body	Assist Step Controller																																																											
C	2013	Tahoe	Body	Body Control Module																																																											
C	2013	Tahoe	Body	Body Control Module (aux.)																																																											
C	2013	Tahoe	Body	Digital Radio Receiver																																																											
C	2013	Tahoe	Body	Driver Door Switch																																																											
C	2013	Tahoe	Body	HVAC Control Module Auto																																																											
C	2013	Tahoe	Body	HVAC Control Module Manual																																																											
C	2013	Tahoe	Body	Instrument Panel Cluster																																																											
C	2013	Tahoe	Body	Left Side Object Detection Module																																																											
C	2013	Tahoe	Body	Lift Gate Module																																																											
C	2013	Tahoe	Body	Memory Seat Module																																																											
C	2013	Tahoe	Body	Navigation Radio																																																											
C	2013	Tahoe	Body	Park Assist Module																																																											
C	2013	Tahoe	Body	Passenger Door Switch																																																											
C	2013	Tahoe	Body	Passenger Presence System																																																											
C	2013	Tahoe	Body	Radio																																																											
C	2013	Tahoe	Body	Rear Heated Seat Module																																																											
C	2013	Tahoe	Body	Rear HVAC/RSA																																																											
C	2013	Tahoe	Body	Right Side Object Detection Module																																																											
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																											
C	2013	Tahoe	Body	Theft Deterrent Module																									V	V	V	V																															
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2013	Tahoe Hybrid	Body	Body Control Module																																																											
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2013	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2013	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2013	Tahoe Hybrid	Body	Navigation Radio																																																										
C	2013	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2013	Tahoe Hybrid	Body	Radio																																																										
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module																									V	V	V	V																														
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
C	2014	Captiva (3GN)	Body	Body Control Module																																																										
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Captiva (3GN)	Body	Passenger Presence Module																																																										
C	2014	Captiva (3GN)	Body	Instrument Cluster																																																										
C	2014	Captiva (3GN)	Body	Radio																																																										
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Captiva (3GN)	Body	HVAC Control Module																																																										
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																										
C	2014	Captiva (3GN)	Body	Theft Deterrent Module				V	V																																																					
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																										
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Captiva (Other)	Body	Instrument Cluster																																																										
C	2014	Captiva (Other)	Body	Headlamp Control Module																																																										
C	2014	Captiva (Other)	Body	HVAC Control Module																																																										
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)				V	V	V	V																																																			
C	2014	Captiva (Other)	Body	Theft Deterrent Module				V	V																																																					
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																										
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																										
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																										
C	2014	Cheyenne	Chassis	Power Steering Control Module																																																										
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Cheyenne	Body	Body Control Module																																																										
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Cheyenne	Body	Passenger Presence Module																																																										
C	2014	Cheyenne	Body	Instrument Cluster																																																										
C	2014	Cheyenne	Body	Radio Control																																																										
C	2014	Cheyenne	Body	HVAC Control																																																										
C	2014	Cheyenne	Body	Radio																																																										
C	2014	Cheyenne	Body	Amplifier																																																										
C	2014	Cheyenne	Body	Media Disc Player																																																										
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																										
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
C	2014	Cheyenne	Body	HVAC Control Module																																																										
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																										
C	2014	Cheyenne	Body	Parking Assist Control Module																																																										
C	2014	Cheyenne	Body	Frontview Camera Module																																																										
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																										
C	2014	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado	Chassis	Parking Brake Control Module																																																										
C	2014	Silverado	Chassis	Power Steering Control Module																																																										
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Silverado	Body	Body Control Module																																																										
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado	Body	Passenger Presence Module																																																										
C	2014	Silverado	Body	Instrument Cluster																																																										
C	2014	Silverado	Body	Radio Control																																																										
C	2014	Silverado	Body	HVAC Control																																																										
C	2014	Silverado	Body	Radio																																																										
C	2014	Silverado	Body	Amplifier																																																										
C	2014	Silverado	Body	Media Disc Player																																																										
C	2014	Silverado	Body	Human Machine Interface Control Module																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2014	Silverado	Body	Parking Assist Control Module																																																										
C	2014	Silverado	Body	Frontview Camera Module																																																										
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																V	V																										
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Suspension Control Module																																																										
C	2014	Silverado HD	Body	Body Control Module																																																										
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado HD	Body	Passenger Presence Module																																																										
C	2014	Silverado HD	Body	Instrument Cluster																																																										
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
C	2014	Silverado HD	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2014	Silverado HD	Body	Navigation Radio																																																										
C	2014	Silverado HD	Body	Uplevel Radio																																																										
C	2014	Silverado HD	Body	Amplifier																																																										
C	2014	Silverado HD	Body	Rear Audio Control Module																																																										
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																										
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																										
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Silverado HD	Body	Seat Memory Control Module	V	V	V																																																								
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																										
C	2014	Silverado HD	Body	Parking Assist Control Module																																																										
C	2014	Silverado HD	Body	Theft Deterrent Module				V	V																																																					
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																										
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																										
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																										
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2014	Suburban	Chassis	Parking Brake Control Module																																																										
C	2014	Suburban	Chassis	Suspension Control Module																																																										
C	2014	Suburban	Body	Body Control Module																																																										
C	2014	Suburban	Body	Auxiliary Body Control Module																																																										
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Suburban	Body	Passenger Presence Module																																																										
C	2014	Suburban	Body	Instrument Cluster																																																										
C	2014	Suburban	Body	Base Radio																																																										
C	2014	Suburban	Body	Navigation Radio																																																										
C	2014	Suburban	Body	Uplevel Radio																																																										
C	2014	Suburban	Body	Amplifier																																																										
C	2014	Suburban	Body	Rear Audio Control Module																																																										
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																										
C	2014	Suburban	Body	Personal Audio Link Control Module																																																										
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Suburban	Body	Liftgate Control Module																																												V														
C	2014	Suburban	Body	Seat Memory Control Module	V	V	V																																																							
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2014	Suburban	Body	Assist Step Control Module																																																									
C	2014	Suburban	Body	Right Side Object Detection Control Module																																																										
C	2014	Suburban	Body	Left Side Object Detection Control Module																																																										
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																										
C	2014	Suburban	Body	Parking Assist Control Module																																																										
C	2014	Suburban	Body	Theft Deterrent Module				V	V																																																					
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																										
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																									
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																									
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																										
C	2014	Tahoe	Chassis	Suspension Control Module																																																										
C	2014	Tahoe	Body	Body Control Module																																																										
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																										
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Tahoe	Body	Passenger Presence Module																																																										
C	2014	Tahoe	Body	Instrument Cluster																																																										
C	2014	Tahoe	Body	Base Radio																																																										
C	2014	Tahoe	Body	Navigation Radio																																																										
C	2014	Tahoe	Body	Uplevel Radio																																																										
C	2014	Tahoe	Body	Amplifier																																																										
C	2014	Tahoe	Body	Rear Audio Control Module																																																										
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																										
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																										
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Tahoe	Body	Liftgate Control Module																																												V															
C	2014	Tahoe	Body	Seat Memory Control Module	V	V	V																																																							
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																																										
C	2014	Tahoe	Body	Assist Step Control Module																																																										
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																																										
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																																										
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																										
C	2014	Tahoe	Body	Parking Assist Control Module																																																										
C	2014	Tahoe	Body	Theft Deterrent Module				V	V																																																					
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2015	Captiva (3GN)	Body	Body Control Module																																																											
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																																											
C	2015	Captiva (3GN)	Body	Instrument Cluster																																																											
C	2015	Captiva (3GN)	Body	Radio																																																											
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																											
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																											
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																											
C	2015	Captiva (3GN)	Body	HVAC Control Module																																																											
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																											
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																											
C	2015	Captiva (3GN)	Body	Theft Deterrent Module				V	V																																																						
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																											
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																											
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																											
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																											
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Captiva (Other)	Body	Instrument Cluster																																																											
C	2015	Captiva (Other)	Body	Headlamp Control Module																																																											
C	2015	Captiva (Other)	Body	HVAC Control Module																																																											
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)				V	V	V	V																																																				
C	2015	Captiva (Other)	Body	Theft Deterrent Module				V	V																																																						
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																											
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																								
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																								
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																V	V																								
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																								
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																								
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																								
C	2015	Cheyenne	Chassis	Power Steering Control Module																																																								
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2015	Cheyenne	Chassis	Suspension Control Module																																																								
C	2015	Cheyenne	Body	Body Control Module																																																								
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2015	Cheyenne	Body	Passenger Presence Module																																																								
C	2015	Cheyenne	Body	Instrument Cluster																																																								
C	2015	Cheyenne	Body	Radio Controls																																																								
C	2015	Cheyenne	Body	HVAC Controls																																																								
C	2015	Cheyenne	Body	Radio																																																								
C	2015	Cheyenne	Body	Amplifier																																																								
C	2015	Cheyenne	Body	Media Disc Player																																																								
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																								
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																								
C	2015	Cheyenne	Body	HVAC Control Module																																																								
C	2015	Cheyenne	Body	Parking Assist Control Module																																																								
C	2015	Cheyenne	Body	Frontview Camera Module																																																								
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																								
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																								
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																								
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																V	V																								
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																								
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																								
C	2015	Silverado	Chassis	Electronic Brake Control Module																																																								
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																								
C	2015	Silverado	Chassis	Power Steering Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Silverado	Chassis	Suspension Control Module																																																											
C	2015	Silverado	Body	Body Control Module																																																										
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Silverado	Body	Passenger Presence Module																																																										
C	2015	Silverado	Body	Instrument Cluster																																																										
C	2015	Silverado	Body	Radio Controls																																																										
C	2015	Silverado	Body	HVAC Controls																																																										
C	2015	Silverado	Body	Radio																																																										
C	2015	Silverado	Body	Amplifier																																																										
C	2015	Silverado	Body	Media Disc Player																																																										
C	2015	Silverado	Body	Human Machine Interface Control Module																																																										
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																										
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2015	Silverado	Body	Parking Assist Control Module																																																										
C	2015	Silverado	Body	Frontview Camera Module																																																										
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																										
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																										
C	2015	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Suburban	Chassis	Parking Brake Control Module																																																										
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Suburban	Chassis	Power Steering Control Module																																																										
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Suburban	Chassis	Suspension Control Module																																																										
C	2015	Suburban	Body	Body Control Module																																																										
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Suburban	Body	Passenger Presence Module																																																										
C	2015	Suburban	Body	Instrument Cluster																																																										
C	2015	Suburban	Body	Radio Controls																																																										
C	2015	Suburban	Body	HVAC Controls																																																										
C	2015	Suburban	Body	Radio																																																										
C	2015	Suburban	Body	Amplifier																																																										
C	2015	Suburban	Body	Media Disc Player																																																										
C	2015	Suburban	Body	Human Machine Interface Control Module																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Suburban	Body	HVAC Control Module																																																										
C	2015	Suburban	Body	Liftgate Control Module																																					V	V	V	V	V	V																
C	2015	Suburban	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2015	Suburban	Body	Assist Step Control Module																																																								
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																								
C	2015	Suburban	Body	Parking Assist Control Module																																																								
C	2015	Suburban	Body	Frontview Camera Module																																																								
C	2015	Suburban	Body	Steering Column Lock Control Module																																																								
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																								
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																															V	V																								
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																															V	V																								
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																															V	V																								
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																								
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																								
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																								
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																																								
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																								
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																								
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																								
C	2015	Tahoe	Chassis	Power Steering Control Module																																																								
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2015	Tahoe	Chassis	Suspension Control Module																																																								
C	2015	Tahoe	Body	Body Control Module																																																								
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2015	Tahoe	Body	Passenger Presence Module																																																								
C	2015	Tahoe	Body	Instrument Cluster																																																								
C	2015	Tahoe	Body	Radio Controls																																																								
C	2015	Tahoe	Body	HVAC Controls																																																								
C	2015	Tahoe	Body	Radio																																																								
C	2015	Tahoe	Body	Amplifier																																																								
C	2015	Tahoe	Body	Media Disc Player																																																								
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																								
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																								
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																								
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2015	Tahoe	Body	HVAC Control Module																																																								
C	2015	Tahoe	Body	Liftgate Control Module																																				V	V	V	V	V	V															
C	2015	Tahoe	Body	Keyless Entry Control Module																																																								
C	2015	Tahoe	Body	Assist Step Control Module																																																								
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																								
C	2015	Tahoe	Body	Parking Assist Control Module																																																								
C	2015	Tahoe	Body	Frontview Camera Module																																																								
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																								
C	2015	Tahoe	Body	Battery Energy Control Module																																																								
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																											
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																											
C	2016	Captiva (3GN)	Body	Body Control Module																																																											
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																											
C	2016	Captiva (3GN)	Body	Radio																																																											
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																											
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																											
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																											
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																											
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																											
C	2016	Captiva (3GN)	Body	Theft Deterrent Module				V	V																																																						
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																											
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																											
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																											
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																											
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Captiva (Other)	Body	Instrument Cluster																																																											
C	2016	Captiva (Other)	Body	Headlamp Control Module																																																											
C	2016	Captiva (Other)	Body	Radio																																																											
C	2016	Captiva (Other)	Body	HVAC Control Module																																																											
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																											
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																											
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)				V	V	V	V																																																				
C	2016	Captiva (Other)	Body	Theft Deterrent Module				V	V																																																						
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																															V	V																								
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																															V	V																								
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																															V	V																								
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																															V	V																								
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																								
C	2016	Cheyenne	Chassis	Power Steering Control Module																																																								
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2016	Cheyenne	Chassis	Suspension Control Module																																																								
C	2016	Cheyenne	Body	Body Control Module																																																								
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2016	Cheyenne	Body	Passenger Presence Module																																																								
C	2016	Cheyenne	Body	Instrument Cluster																																																								
C	2016	Cheyenne	Body	Radio Controls																																																								
C	2016	Cheyenne	Body	HVAC Controls																																																								
C	2016	Cheyenne	Body	Radio																																																								
C	2016	Cheyenne	Body	Amplifier																																																								
C	2016	Cheyenne	Body	Media Disc Player																																																								
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																								
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																								
C	2016	Cheyenne	Body	HVAC Control Module																																																								
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																								
C	2016	Cheyenne	Body	Parking Assist Control Module																																																								
C	2016	Cheyenne	Body	Frontview Camera Module																																																								
C	2016	Cheyenne	Body	Frontview Camera Module																																																								
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																								
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																								
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																								
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																								
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																													V												
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																													V			V	V		V				V		
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																								
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																								
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																															V	V																								
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																															V	V																								
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																															V	V																								
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																															V	V																								
C	2016	Silverado	Chassis	Electronic Brake Control Module																																																							

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2016	Silverado	Chassis	Power Steering Control Module																																																									
C	2016	Silverado	Chassis	Power Steering Control Module																																																										
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Silverado	Chassis	Suspension Control Module																																																										
C	2016	Silverado	Body	Body Control Module																																																										
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Silverado	Body	Passenger Presence Module																																																										
C	2016	Silverado	Body	Instrument Cluster																																																										
C	2016	Silverado	Body	Radio Controls																																																										
C	2016	Silverado	Body	HVAC Controls																																																										
C	2016	Silverado	Body	Radio (IO3)																																																										
C	2016	Silverado	Body	Radio (IOB)																																																										
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
C	2016	Silverado	Body	Amplifier																																																										
C	2016	Silverado	Body	Media Disc Player																																																										
C	2016	Silverado	Body	Human Machine Interface Control Module																																																										
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																										
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																										
C	2016	Silverado	Body	Parking Assist Control Module																																																										
C	2016	Silverado	Body	Frontview Camera Module																																																										
C	2016	Silverado	Body	Frontview Camera Module																																																										
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																									
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																									
C	2016	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
C	2016	Suburban	Chassis	Parking Brake Control Module																																																										
C	2016	Suburban	Chassis	Power Steering Control Module																																																										
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Suburban	Chassis	Suspension Control Module																																																										
C	2016	Suburban	Body	Body Control Module																																																										
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Suburban	Body	Passenger Presence Module																																																										
C	2016	Suburban	Body	Instrument Cluster																																																										
C	2016	Suburban	Body	Radio Controls																																																										
C	2016	Suburban	Body	HVAC Controls																																																										
C	2016	Suburban	Body	Radio																																																										
C	2016	Suburban	Body	Amplifier																																																										
C	2016	Suburban	Body	Media Disc Player																																																										
C	2016	Suburban	Body	Human Machine Interface Control Module																																																										
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																																										
C	2016	Suburban	Body	HVAC Control Module																																																										
C	2016	Suburban	Body	Liftgate Control Module																																					V	V	V	V	V	V															

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																									
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																									
C	2016	Suburban	Body	Keyless Entry Control Module																																																									
C	2016	Suburban	Body	Assist Step Control Module																																																									
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																									
C	2016	Suburban	Body	Parking Assist Control Module																																																									
C	2016	Suburban	Body	Frontview Camera Module																																																									
C	2016	Suburban	Body	Steering Column Lock Control Module																																																									
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																									
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																									
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																																									
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																									
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																									
C	2016	Tahoe	Chassis	Power Steering Control Module																																																									
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2016	Tahoe	Chassis	Suspension Control Module																																																									
C	2016	Tahoe	Body	Body Control Module																																																									
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Tahoe	Body	Passenger Presence Module																																																									
C	2016	Tahoe	Body	Instrument Cluster																																																									
C	2016	Tahoe	Body	Radio Controls																																																									
C	2016	Tahoe	Body	HVAC Controls																																																									
C	2016	Tahoe	Body	Radio																																																									
C	2016	Tahoe	Body	Amplifier																																																									
C	2016	Tahoe	Body	Media Disc Player																																																									
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																									
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																									
C	2016	Tahoe	Body	HVAC Control Module																																																									
C	2016	Tahoe	Body	Liftgate Control Module																																						V	V	V	V	V	V														
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																									
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																									
C	2016	Tahoe	Body	Keyless Entry Control Module																																																									
C	2016	Tahoe	Body	Assist Step Control Module																																																									
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																									
C	2016	Tahoe	Body	Parking Assist Control Module																																																									
C	2016	Tahoe	Body	Frontview Camera Module																																																									
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																									
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																									
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																									
E	2004	ALL	Chassis	Electronic Brake Control Module																																																									
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																									
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																									
E	2006	ALL	Chassis	Electronic Brake Control Module																																																									
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																									
E	2007	ALL	Chassis	Electronic Brake Control Module																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																													
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																													

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																															
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																																
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																																
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																																
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																											
G	2004	Express/Savana	Chassis	VSES																																																											
G	2004	Express/Savana	Body	Body Control Module																																																											
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																											
G	2004	Express/Savana	Body	OnStar																																																											
G	2004	Express/Savana	Body	Base Radio																																																											
G	2004	Express/Savana	Body	Uplevel Radio																																																											
G	2004	Express/Savana	Body	Remote Function Actuation																																																											
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																																
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																																
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																																
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																																
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																																
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																																
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																																
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																											
G	2004	Express Access/Savana Pro	Chassis	VSES																																																											
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
G	2004	Express Access/Savana Pro	Body	OnStar																																																											
G	2004	Express Access/Savana Pro	Body	Base Radio																																																											
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																											
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																																
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																											
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control											V																																																
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																											
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control											V																																																
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module											V																																															
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																															
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																															
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																															
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																															
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2005	Express/Savana	Chassis	VSES																																																										
G	2005	Express/Savana	Body	Body Control Module																																																										
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2005	Express/Savana	Body	Base Radio																																																										
G	2005	Express/Savana	Body	Uplevel Radio																																																										
G	2005	Express/Savana	Body	Remote Function Actuation																																																										
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control											V																																															
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control											V																																															
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module											V																																															
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																																
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																																
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																																
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																																
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2005	Express Access/Savana Pro	Chassis	VSES																																																										
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2005	Express Access/Savana Pro	Body	Base Radio																																																										
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control											V																																															
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control											V																																															

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																															
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																															
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																															
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																															
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																																
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2006	Express/Savana	Chassis	VSES																																																										
G	2006	Express/Savana	Body	Body Control Module																																																										
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2006	Express/Savana	Body	Passenger Presence System																																																										
G	2006	Express/Savana	Body	Base Radio																																																										
G	2006	Express/Savana	Body	Uplevel Radio																																																										
G	2006	Express/Savana	Body	Remote Function Actuation																																																										
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control											V																																															
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control											V																																															
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																															
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																															
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																															
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																															
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																																
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2006	Express Access/Savana Pro	Chassis	VSES																																																										
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2006	Express Access/Savana Pro	Body	Base Radio																																																										
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control											V																																															
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control											V																																															
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																															
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																															
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																															
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																															
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																															
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																																
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																						V																																				
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express/Savana	Body	Body Control Module																																																										
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2007	Express/Savana	Body	Passenger Presence System																																																										
G	2007	Express/Savana	Body	Base Radio																																																										
G	2007	Express/Savana	Body	Uplevel Radio																																																										
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control											V																																															
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control											V																																															
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																															
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																															
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																															
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																															
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																														
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																														
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																						V																																			
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2007	Express Access/Savana Pro	Body	Radio																																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																														
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2008	Express/Savana	Body	Body Control Module																																																								
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2008	Express/Savana	Body	Passenger Presence System																																																								
G	2008	Express/Savana	Body	Radio																																																								
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2008	Express/Savana	Body	Rollover Sensor																																																								
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2008	Express/Savana	Body	Theft Deterrent Module																										V	V	V	V																											
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2008	Express Access/Savana Pro	Body	Radio																																																										
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																														
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																																
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2009	Express/Savana	Body	Body Control Module																																																										
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2009	Express/Savana	Body	Passenger Presence System																																																										
G	2009	Express/Savana	Body	Radio																																																										
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express/Savana	Body	Rollover Sensor																																																										
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2009	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																														
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																																
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2009	Express Access/Savana Pro	Body	Radio																																																										
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																														
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																																
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																																
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2010	Express/Savana	Body	Body Control Module																																																										
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2010	Express/Savana	Body	Passenger Presence System																																																										
G	2010	Express/Savana	Body	Radio																																																										
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2010	Express/Savana	Body	Rollover Sensor																																																										
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2010	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																														
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																																
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																																
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2010	Express Access/Savana Pro	Body	Radio																																																										
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																														
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2011	Express/Savana	Body	Body Control Module																																																										
G	2011	Express/Savana	Body	Digital Radio Receiver																																																										
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2011	Express/Savana	Body	Passenger Presence System																																																										
G	2011	Express/Savana	Body	Radio																																																										
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2011	Express/Savana	Body	Rollover Sensor																																																										
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2011	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																														
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																																
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2011	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2011	Express Access/Savana Pro	Body	Radio																																																									
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																													
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2012	Express/Savana	Body	Body Control Module																																																									
G	2012	Express/Savana	Body	Digital Radio Receiver																																																									
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2012	Express/Savana	Body	Passenger Presence System																																																									
G	2012	Express/Savana	Body	Radio																																																									
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2012	Express/Savana	Body	Rollover Sensor																																																									
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2012	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																													
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																														
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2012	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2012	Express Access/Savana Pro	Body	Radio																																																								
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																												
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																														
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2013	Express/Savana	Body	Body Control Module																																																								
G	2013	Express/Savana	Body	Digital Radio Receiver																																																								
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2013	Express/Savana	Body	Navigation Radio																																																								
G	2013	Express/Savana	Body	Park Assist Module																																																								
G	2013	Express/Savana	Body	Passenger Presence System																																																								
G	2013	Express/Savana	Body	Radio																																																								
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2013	Express/Savana	Body	Rollover Sensor																																																								
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2013	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																												
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2013	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																									
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																									
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2013	Express Access/Savana Pro	Body	Radio																																																									
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																										V	V	V	V																												
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																									
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																									
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																									
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																									
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																									
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																									
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																									
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
G	2014	Express	Chassis	Electronic Brake Control Module																																																									
G	2014	Express	Body	Body Control Module																																																									
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
G	2014	Express	Body	Passenger Presence Module																																																									
G	2014	Express	Body	Rollover Sensor Module																																																									
G	2014	Express	Body	Instrument Cluster																																																									
G	2014	Express	Body	Chime Alarm Control Module																																																									
G	2014	Express	Body	Base Radio																																																									
G	2014	Express	Body	Navigation Radio																																																									
G	2014	Express	Body	Uplevel Radio																																																									
G	2014	Express	Body	Digital Radio Receiver Control Module																																																									
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																									
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																									
G	2014	Express	Body	Auxiliary Heater Control Module																																																									
G	2014	Express	Body	Remote Control Door Lock Receiver																																																									
G	2014	Express	Body	Parking Assist Control Module																																																									
G	2014	Express	Body	Theft Deterrent Module				V	V																																																				

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2014	Savana	Chassis	Electronic Brake Control Module																																																										
G	2014	Savana	Body	Body Control Module																																																									
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2014	Savana	Body	Passenger Presence Module																																																										
G	2014	Savana	Body	Rollover Sensor Module																																																										
G	2014	Savana	Body	Instrument Cluster																																																									
G	2014	Savana	Body	Chime Alarm Control Module																																																										
G	2014	Savana	Body	Base Radio																																																									
G	2014	Savana	Body	Navigation Radio																																																									
G	2014	Savana	Body	Uplevel Radio																																																									
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2014	Savana	Body	Auxiliary Heater Control Module																																																										
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
G	2014	Savana	Body	Parking Assist Control Module																																																										
G	2014	Savana	Body	Theft Deterrent Module				V	V																																																				
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2015	Express	Chassis	Electronic Brake Control Module																																																										
G	2015	Express	Body	Body Control Module																																																									
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2015	Express	Body	Rollover Sensor Module																																																										
G	2015	Express	Body	Instrument Cluster																																																									
G	2015	Express	Body	Digital Radio Receiver Control Module																																																										
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2015	Express	Body	Auxiliary Heater Control Module																																																										
G	2015	Express	Body	Remote Control Door Lock Receiver																																																										
G	2015	Express	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2015	Express	Body	Theft Deterrent Module				V	V																																																					
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2015	Savana	Chassis	Electronic Brake Control Module																																																										
G	2015	Savana	Body	Body Control Module																																																									
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2015	Savana	Body	Rollover Sensor Module																																																										
G	2015	Savana	Body	Instrument Cluster																																																										
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2015	Savana	Body	Auxiliary Heater Control Module																																																										
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
G	2015	Savana	Body	Parking Assist Control Module																																																										
G	2015	Savana	Body	Theft Deterrent Module				V	V																																																					
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2016	Express	Chassis	Electronic Brake Control Module																																																										
G	2016	Express	Body	Body Control Module																																																									
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2016	Express	Body	Instrument Cluster																																																									
G	2016	Express	Body	Chime Alarm Control Module																																																									
G	2016	Express	Body	Base Radio																																																									
G	2016	Express	Body	Navigation Radio																																																									
G	2016	Express	Body	Uplevel Radio																																																									
G	2016	Express	Body	Digital Radio Receiver Control Module																																																										
G	2016	Express	Body	Telematics Communication Interface Control Module																																																										
G	2016	Express	Body	Auxiliary Heater Control Module																																																										
G	2016	Express	Body	Remote Control Door Lock Receiver																																																										
G	2016	Express	Body	Parking Assist Control Module																																																										
G	2016	Express	Body	Theft Deterrent Module				V	V																																																					
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
G	2016	Savana	Chassis	Electronic Brake Control Module																																																									
G	2016	Savana	Body	Body Control Module																																																								
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
G	2016	Savana	Body	Instrument Cluster																																																								
G	2016	Savana	Body	Chime Alarm Control Module																																																								
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																								
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																								
G	2016	Savana	Body	Auxiliary Heater Control Module																																																								
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																								
G	2016	Savana	Body	Parking Assist Control Module																																																								
G	2016	Savana	Body	Theft Deterrent Module				V	V																																																				
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																														
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2004	Express/Savana	Chassis	VSES																																																									
H	2004	Express/Savana	Body	Body Control Module																																																								
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2004	Express/Savana	Body	OnStar																																																								
H	2004	Express/Savana	Body	Base Radio																																																								
H	2004	Express/Savana	Body	Uplevel Radio																																																								
H	2004	Express/Savana	Body	Remote Function Actuation																																																								
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																													
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2004	Express Access/Savana Pro	Chassis	VSES																																																								
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2004	Express Access/Savana Pro	Body	OnStar																																																								
H	2004	Express Access/Savana Pro	Body	Base Radio																																																								
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																													
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																													
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2005	Express/Savana	Chassis	VSES																																																								
H	2005	Express/Savana	Body	Body Control Module																																																								
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2005	Express/Savana	Body	Base Radio																																																								
H	2005	Express/Savana	Body	Uplevel Radio																																																								
H	2005	Express/Savana	Body	Remote Function Actuation																																																								
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																															
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																															
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2005	Express Access/Savana Pro	Chassis	VSES																																																										
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2005	Express Access/Savana Pro	Body	Base Radio																																																										
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																															
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																															
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2006	Express/Savana	Chassis	VSES																																																										
H	2006	Express/Savana	Body	Body Control Module																																																										
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2006	Express/Savana	Body	Passenger Presence System																																																										
H	2006	Express/Savana	Body	Base Radio																																																										
H	2006	Express/Savana	Body	Uplevel Radio																																																										
H	2006	Express/Savana	Body	Remote Function Actuation																																																										
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																															
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																															
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2006	Express Access/Savana Pro	Chassis	VSES																																																										
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2006	Express Access/Savana Pro	Body	Base Radio																																																										
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																															
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																															
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																															

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2007	Express/Savana	Body	Body Control Module																																																									
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2007	Express/Savana	Body	Passenger Presence System																																																									
H	2007	Express/Savana	Body	Base Radio																																																									
H	2007	Express/Savana	Body	Uplevel Radio																																																									
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																														
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																														
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																														
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2007	Express Access/Savana Pro	Body	Base Radio																																																									
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2008	Express/Savana	Body	Body Control Module																																																									
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2008	Express/Savana	Body	Passenger Presence System																																																									
H	2008	Express/Savana	Body	Radio																																																									
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2008	Express/Savana	Body	Rollover Sensor																																																									
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2008	Express/Savana	Body	Theft Deterrent Module																										V	V	V	V																												
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																														
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module																																																										
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																																										
H	2009	Express/Savana	Body	Radio																																																									
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																														
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																												
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2010	Express/Savana	Body	Body Control Module																																																								
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2010	Express/Savana	Body	Passenger Presence System																																																								
H	2010	Express/Savana	Body	Radio																																																								
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2010	Express/Savana	Body	Rollover Sensor																																																								
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2010	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																												
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2010	Express Access/Savana Pro	Body	Radio																																																								
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																												
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2011	Express/Savana	Body	Body Control Module																																																								
H	2011	Express/Savana	Body	Digital Radio Receiver																																																								
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2011	Express/Savana	Body	Passenger Presence System																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2011	Express/Savana	Body	Radio																																																									
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2011	Express/Savana	Body	Rollover Sensor																																																									
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2011	Express/Savana	Body	Theft Deterrent Module																										V	V	V	V																												
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2011	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2011	Express Access/Savana Pro	Body	Radio																																																									
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																										V	V	V	V																												
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2012	Express/Savana	Body	Body Control Module																																																									
H	2012	Express/Savana	Body	Digital Radio Receiver																																																									
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2012	Express/Savana	Body	Passenger Presence System																																																									
H	2012	Express/Savana	Body	Radio																																																									
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2012	Express/Savana	Body	Rollover Sensor																																																									
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2012	Express/Savana	Body	Theft Deterrent Module																										V	V	V	V																												
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2012	Express Access/Savana Pro	Body	Radio																																																										
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																														
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2013	Express/Savana	Body	Body Control Module																																																										
H	2013	Express/Savana	Body	Digital Radio Receiver																																																										
H	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2013	Express/Savana	Body	Navigation Radio																																																										
H	2013	Express/Savana	Body	Park Assist Module																																																										
H	2013	Express/Savana	Body	Passenger Presence System																																																										
H	2013	Express/Savana	Body	Radio																																																										
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2013	Express/Savana	Body	Rollover Sensor																																																										
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2013	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																														
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2013	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																																									
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2013	Express Access/Savana Pro	Body	Radio																																																									
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																										V	V	V	V																												
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																									
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																									
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																									
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																									
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																									
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																									
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																									
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2014	Express	Chassis	Electronic Brake Control Module																																																									
H	2014	Express	Body	Body Control Module																																																									
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
H	2014	Express	Body	Passenger Presence Module																																																									
H	2014	Express	Body	Rollover Sensor Module																																																									
H	2014	Express	Body	Instrument Cluster																																																									
H	2014	Express	Body	Chime Alarm Control Module																																																									
H	2014	Express	Body	Base Radio																																																									
H	2014	Express	Body	Navigation Radio																																																									
H	2014	Express	Body	Uplevel Radio																																																									
H	2014	Express	Body	Digital Radio Receiver Control Module																																																									
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																									
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																									
H	2014	Express	Body	Auxiliary Heater Control Module																																																									
H	2014	Express	Body	Remote Control Door Lock Receiver																																																									
H	2014	Express	Body	Parking Assist Control Module																																																									
H	2014	Express	Body	Theft Deterrent Module				V	V																																																				
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																									
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																									
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																									
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																									
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																									
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																									
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																									
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2014	Savana	Chassis	Electronic Brake Control Module																																																											
H	2014	Savana	Body	Body Control Module																																																										
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Savana	Body	Passenger Presence Module																																																										
H	2014	Savana	Body	Rollover Sensor Module																																																										
H	2014	Savana	Body	Instrument Cluster																																																										
H	2014	Savana	Body	Chime Alarm Control Module																																																										
H	2014	Savana	Body	Base Radio																																																										
H	2014	Savana	Body	Navigation Radio																																																										
H	2014	Savana	Body	Uplevel Radio																																																										
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2014	Savana	Body	Auxiliary Heater Control Module																																																										
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2014	Savana	Body	Parking Assist Control Module																																																										
H	2014	Savana	Body	Theft Deterrent Module				V	V																																																					
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2015	Express	Chassis	Electronic Brake Control Module																																																										
H	2015	Express	Body	Body Control Module																																																										
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Express	Body	Rollover Sensor Module																																																										
H	2015	Express	Body	Instrument Cluster																																																										
H	2015	Express	Body	Digital Radio Receiver Control Module																																																										
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2015	Express	Body	Auxiliary Heater Control Module																																																										
H	2015	Express	Body	Remote Control Door Lock Receiver																																																										
H	2015	Express	Body	Parking Assist Control Module																																																										
H	2015	Express	Body	Theft Deterrent Module				V	V																																																					
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2015	Savana	Chassis	Electronic Brake Control Module																																																										
H	2015	Savana	Body	Body Control Module																																																										
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2015	Savana	Body	Rollover Sensor Module																																																										
H	2015	Savana	Body	Instrument Cluster																																																										
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2015	Savana	Body	Auxiliary Heater Control Module																																																										
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2015	Savana	Body	Parking Assist Control Module																																																										
H	2015	Savana	Body	Theft Deterrent Module				V	V																																																						
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2016	Express	Chassis	Electronic Brake Control Module																																																										
H	2016	Express	Body	Body Control Module																																																										
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Express	Body	Instrument Cluster																																																										
H	2016	Express	Body	Chime Alarm Control Module																																																										
H	2016	Express	Body	Base Radio																																																										
H	2016	Express	Body	Navigation Radio																																																										
H	2016	Express	Body	Uplevel Radio																																																										
H	2016	Express	Body	Digital Radio Receiver Control Module																																																										
H	2016	Express	Body	Telematics Communication Interface Control Module																																																										
H	2016	Express	Body	Auxiliary Heater Control Module																																																										
H	2016	Express	Body	Remote Control Door Lock Receiver																																																										
H	2016	Express	Body	Parking Assist Control Module																																																										
H	2016	Express	Body	Theft Deterrent Module				V	V																																																						
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2016	Savana	Chassis	Electronic Brake Control Module																																																										
H	2016	Savana	Body	Body Control Module																																																										
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Savana	Body	Instrument Cluster																																																										
H	2016	Savana	Body	Chime Alarm Control Module																																																										
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
H	2016	Savana	Body	Auxiliary Heater Control Module																																																										
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2016	Savana	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2016	Savana	Body	Theft Deterrent Module				V	V																																																				
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																									
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																									
J	2004	ALL	Chassis	Electronic Brake Control Module																																																									
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																									
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																									
J	2007	ALL	Chassis	Electronic Brake Control Module																																																									
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																									
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																									
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																									
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																									
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																															
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																															
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																									
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																									
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																									
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																									
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																									
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																									
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																									
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																									
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																									
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																									
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																									
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																																									
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																																									
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																									
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																									
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																									
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																																									
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																									
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																									
J	2013	Tracker	Chassis	Power Steering Control Module																																																									
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2013	Tracker	Body	Body Control Module																																																								
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2013	Tracker	Body	Passenger Presence Module																																																									
J	2013	Tracker	Body	Instrument Cluster																																																								
J	2013	Tracker	Body	Radio																																																								
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																																									
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																																									
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																																									
J	2013	Tracker	Body	Front Seat Heating Control Module																																																									
J	2013	Tracker	Body	Parking Assist Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2013	Tracker	Body	Frontview Camera Module																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																															
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																															
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2013	Trax	Chassis	Electronic Brake Control Module																																																										
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Trax	Chassis	Power Steering Control Module																																																										
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Trax	Body	Body Control Module																																																									
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Trax	Body	Passenger Presence Module																																																										
J	2013	Trax	Body	Instrument Cluster																																																									
J	2013	Trax	Body	Radio																																																									
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Trax	Body	Front Seat Heating Control Module																																																										
J	2013	Trax	Body	Parking Assist Control Module																																																										
J	2013	Trax	Body	Frontview Camera Module																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																									
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																									
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																														
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																														
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																									
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																									
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																									
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																																									
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																									
J	2014	Tracker	Chassis	Power Steering Control Module																																																									
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2014	Tracker	Body	Body Control Module																																																								
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2014	Tracker	Body	Passenger Presence Module																																																									
J	2014	Tracker	Body	Instrument Cluster																																																								
J	2014	Tracker	Body	Radio																																																								
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																																									
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																																									
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																																									
J	2014	Tracker	Body	Front Seat Heating Control Module																																																									
J	2014	Tracker	Body	Parking Assist Control Module																																																									
J	2014	Tracker	Body	Frontview Camera Module																																																									
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																									
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																														
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																														
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																									
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																									
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																									
J	2014	Trax	Chassis	Electronic Brake Control Module																																																									
J	2014	Trax	Chassis	Power Steering Control Module																																																									
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2014	Trax	Body	Body Control Module																																																								
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2014	Trax	Body	Passenger Presence Module																																																									
J	2014	Trax	Body	Instrument Cluster																																																								
J	2014	Trax	Body	Radio																																																								
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
J	2014	Trax	Body	Front Seat Heating Control Module																																																								
J	2014	Trax	Body	Parking Assist Control Module																																																								
J	2014	Trax	Body	Frontview Camera Module																																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																														
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																														
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																									
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2015	Tracker	Chassis	Power Steering Control Module																																																										
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Tracker	Body	Body Control Module																																																										
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Tracker	Body	Instrument Cluster																																																										
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																																										
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Tracker	Body	Front Seat Heating Control Module																																																										
J	2015	Tracker	Body	Parking Assist Control Module																																																										
J	2015	Tracker	Body	Frontview Camera Module																																																										
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission										V																																															
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission										V																																															
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2015	Trax	Powertrain	Chassis Control Module																																																										
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Trax	Chassis	Electronic Brake Control Module																																																										
J	2015	Trax	Chassis	Power Steering Control Module																																																										
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Trax	Body	Body Control Module																																																									
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Trax	Body	Passenger Presence Module																																																										
J	2015	Trax	Body	Instrument Cluster																																																										
J	2015	Trax	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Trax	Body	Seat Memory Control Module																																																										
J	2015	Trax	Body	Front Seat Heating Control Module																																																										
J	2015	Trax	Body	Right Side Object Detection Control Module																																																										
J	2015	Trax	Body	Left Side Object Detection Control Module																																																										
J	2015	Trax	Body	Parking Assist Control Module																																																										
J	2015	Trax	Body	Frontview Camera Module																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																										
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2016	Tracker	Chassis	Power Steering Control Module																																																										
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Tracker	Body	Body Control Module																																																										
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Tracker	Body	Instrument Cluster																																																										
J	2016	Tracker	Body	Trailer Interface Control Module																																																										
J	2016	Tracker	Body	Radio																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Tracker	Body	Front Seat Heating Control Module																																																										
J	2016	Tracker	Body	Parking Assist Control Module																																																										
J	2016	Tracker	Body	Frontview Camera Module																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																									
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																									
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																									
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																									
J	2016	Trax	Powertrain	Chassis Control Module																																																									
J	2016	Trax	Chassis	Electronic Brake Control Module																																																									
J	2016	Trax	Chassis	Power Steering Control Module																																																									
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2016	Trax	Body	Body Control Module																																																									
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2016	Trax	Body	Passenger Presence Module																																																									
J	2016	Trax	Body	Instrument Cluster																																																									
J	2016	Trax	Body	Trailer Interface Control Module																																																									
J	2016	Trax	Body	Radio																																																									
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																									
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																									
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																									
J	2016	Trax	Body	Seat Memory Control Module																																																									
J	2016	Trax	Body	Front Seat Heating Control Module																																																									
J	2016	Trax	Body	Right Side Object Detection Control Module																																																									
J	2016	Trax	Body	Left Side Object Detection Control Module																																																									
J	2016	Trax	Body	Parking Assist Control Module																																																									
J	2016	Trax	Body	Frontview Camera Module																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM											V																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																													
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																													
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																													
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600											V																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600											V																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module										V																																																
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																																
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed											V																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2004	ALL	Chassis	ESC																																																									
K	2004	ALL	Chassis	Rear Wheel Steering																																																										
K	2004	ALL	Chassis	Tire Pressure Monitor																																																										
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2004	ALL	Chassis	VSES																																																									
K	2004	ALL	Body	Amplifier (Bose)																																																										
K	2004	ALL	Body	Body Control Module																																																										
K	2004	ALL	Body	CD Changer																																																										
K	2004	ALL	Body	Chime																																																										
K	2004	ALL	Body	Driver Door Module																																																										
K	2004	ALL	Body	Driver Seat Module																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2004	ALL	Body	Instrument Panel Cluster																																																										
K	2004	ALL	Body	OnStar																																																									
K	2004	ALL	Body	Passenger Door Module																																																									
K	2004	ALL	Body	Passenger Presence System																																																									
K	2004	ALL	Body	Radio Base																																																									
K	2004	ALL	Body	Radio Uplevel																																																									
K	2004	ALL	Body	Radio Navigation																																																									
K	2004	ALL	Body	Rear Aux. Climate Module																																																										
K	2004	ALL	Body	Rear HVAC																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2004	ALL	Body	Rear Seat Audio																																																										
K	2004	ALL	Body	Rear Seat Entertainment																																																										
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2004	ALL	Body	Vehicle Theft Deterrent																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM											V																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module											V																																														
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600											V																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600											V																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																														
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																															
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed											V																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2005	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM											V																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																														
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module											V																																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																															
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																															
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600											V																																															
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600											V																																															
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																															
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module										V																																																
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																																
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed											V																																															
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2006	ALL	Chassis	ESC																																																									
K	2006	ALL	Chassis	Tire Pressure Monitor																																																										
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2006	ALL	Chassis	VSES																																																									
K	2006	ALL	Body	Amplifier (Bose)																																																										
K	2006	ALL	Body	Body Control Module																																																										
K	2006	ALL	Body	CD Changer																																																										
K	2006	ALL	Body	Chime																																																										
K	2006	ALL	Body	Disc Player and Video Display																																																										
K	2006	ALL	Body	Driver Door Module																																																										
K	2006	ALL	Body	Driver Seat Module																																																										
K	2006	ALL	Body	Generator Battery Control Module																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2006	ALL	Body	Instrument Panel Cluster																																																										
K	2006	ALL	Body	Passenger Door Module																																																										
K	2006	ALL	Body	Passenger Presence System																																																										
K	2006	ALL	Body	Base Radio																																																										
K	2006	ALL	Body	Uplevel Radio																																																										
K	2006	ALL	Body	Navigation Radio																																																										
K	2006	ALL	Body	Rear Aux. Climate Module																																																										
K	2006	ALL	Body	Rear HVAC																																																										
K	2006	ALL	Body	Rear Seat Audio																																																										
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2006	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																																										
K	2007	Avalanche	Body	Amplifier (Bose)																																																										
K	2007	Avalanche	Body	Assist Step Controller																																																										
K	2007	Avalanche	Body	Body Control Module																																																										
K	2007	Avalanche	Body	Body Control Module (aux.)																																																										
K	2007	Avalanche	Body	Digital Radio Receiver																																																										
K	2007	Avalanche	Body	Driver Door Switch																																																										
K	2007	Avalanche	Body	HVAC Control Module Auto																																																										
K	2007	Avalanche	Body	HVAC Control Module Manual																																																										
K	2007	Avalanche	Body	Instrument Panel Cluster																																																										
K	2007	Avalanche	Body	Memory Seat Module																																																										
K	2007	Avalanche	Body	Park Assist Module																																																										
K	2007	Avalanche	Body	Passenger Door Switch																																																										
K	2007	Avalanche	Body	Passenger Presence System																																																										
K	2007	Avalanche	Body	Radio																																																										
K	2007	Avalanche	Body	Rear Heated Seat Module																																																										
K	2007	Avalanche	Body	Rear HVAC/RSA																																																										
K	2007	Avalanche	Body	Rollover Sensor																																																										
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2007	Avalanche	Body	Theft Deterrent Module																										V	V	V	V																													
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Suburban	Chassis	Electronic Suspension Control																																																									
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																									
K	2007	Suburban	Body	Amplifier (Bose)																																																									
K	2007	Suburban	Body	Assist Step Controller																																																									
K	2007	Suburban	Body	Body Control Module																																																									
K	2007	Suburban	Body	Body Control Module (aux.)																																																									
K	2007	Suburban	Body	Digital Radio Receiver																																																									
K	2007	Suburban	Body	Driver Door Switch																																																									
K	2007	Suburban	Body	HVAC Control Module Auto																																																									
K	2007	Suburban	Body	HVAC Control Module Manual																																																									
K	2007	Suburban	Body	Instrument Panel Cluster																																																									
K	2007	Suburban	Body	Lift Gate Module																																																									
K	2007	Suburban	Body	Memory Seat Module																																																									
K	2007	Suburban	Body	Park Assist Module																																																									
K	2007	Suburban	Body	Passenger Door Switch																																																									
K	2007	Suburban	Body	Passenger Presence System																																																									
K	2007	Suburban	Body	Radio																																																									
K	2007	Suburban	Body	Rear Heated Seat Module																																																									
K	2007	Suburban	Body	Rear HVAC/RSA																																																									
K	2007	Suburban	Body	Rollover Sensor																																																									
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																																									
K	2007	Suburban	Body	Theft Deterrent Module																									V	V	V	V																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																									
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																									
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																																
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Silverado	Chassis	Electronic Suspension Control																																																										
K	2007	Silverado	Chassis	Trailer Brake Control Module																																																										
K	2007	Silverado	Body	Amplifier (Bose)																																																										
K	2007	Silverado	Body	Body Control Module																																																										
K	2007	Silverado	Body	Body Control Module (aux.)																																																										
K	2007	Silverado	Body	Digital Radio Receiver																																																										
K	2007	Silverado	Body	Driver Door Switch																																																										
K	2007	Silverado	Body	HVAC Control Module Auto																																																										
K	2007	Silverado	Body	HVAC Control Module Manual																																																										
K	2007	Silverado	Body	Instrument Panel Cluster																																																										
K	2007	Silverado	Body	Memory Seat Module																																																										
K	2007	Silverado	Body	Park Assist Module																																																										
K	2007	Silverado	Body	Passenger Door Switch																																																										
K	2007	Silverado	Body	Passenger Presence System																																																										
K	2007	Silverado	Body	Radio																																																										
K	2007	Silverado	Body	Rear Heated Seat Module																																																										
K	2007	Silverado	Body	Rear HVAC/RSA																																																										
K	2007	Silverado	Body	Rollover Sensor																																																										
K	2007	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2007	Silverado	Body	Theft Deterrent Module																										V	V	V	V																													
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2007	Tahoe	Body	Amplifier (Bose)																																																										
K	2007	Tahoe	Body	Assist Step Controller																																																										
K	2007	Tahoe	Body	Body Control Module																																																										
K	2007	Tahoe	Body	Body Control Module (aux.)																																																										
K	2007	Tahoe	Body	Digital Radio Receiver																																																										
K	2007	Tahoe	Body	Driver Door Switch																																																										
K	2007	Tahoe	Body	HVAC Control Module Auto																																																										
K	2007	Tahoe	Body	HVAC Control Module Manual																																																										
K	2007	Tahoe	Body	Instrument Panel Cluster																																																										
K	2007	Tahoe	Body	Lift Gate Module																																																										
K	2007	Tahoe	Body	Memory Seat Module																																																										
K	2007	Tahoe	Body	Park Assist Module																																																										
K	2007	Tahoe	Body	Passenger Door Switch																																																										
K	2007	Tahoe	Body	Passenger Presence System																																																										
K	2007	Tahoe	Body	Radio																																																										
K	2007	Tahoe	Body	Rear Heated Seat Module																																																										
K	2007	Tahoe	Body	Rear HVAC/RSA																																																										
K	2007	Tahoe	Body	Rollover Sensor																																																										
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2007	Tahoe	Body	Theft Deterrent Module																										V	V	V	V																													
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																										
K	2008	Avalanche	Body	Amplifier (Bose)																																																										
K	2008	Avalanche	Body	Assist Step Controller																																																										
K	2008	Avalanche	Body	Body Control Module																																																										
K	2008	Avalanche	Body	Body Control Module (aux.)																																																										
K	2008	Avalanche	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2008	Avalanche	Body	Driver Door Switch																																																									
K	2008	Avalanche	Body	HVAC Control Module Auto																																																									
K	2008	Avalanche	Body	HVAC Control Module Manual																																																									
K	2008	Avalanche	Body	Instrument Panel Cluster																																																									
K	2008	Avalanche	Body	Memory Seat Module																																																									
K	2008	Avalanche	Body	Park Assist Module																																																									
K	2008	Avalanche	Body	Passenger Door Switch																																																									
K	2008	Avalanche	Body	Passenger Presence System																																																									
K	2008	Avalanche	Body	Radio																																																									
K	2008	Avalanche	Body	Rear Heated Seat Module																																																									
K	2008	Avalanche	Body	Rear HVAC/RSA																																																									
K	2008	Avalanche	Body	Rollover Sensor																																																									
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																									
K	2008	Avalanche	Body	Theft Deterrent Module																										V	V	V	V																												
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2008	Suburban	Chassis	EBCM Under 8600 GVW																																																									
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2008	Suburban	Chassis	Electronic Suspension Control																																																									
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																									
K	2008	Suburban	Body	Amplifier (Bose)																																																									
K	2008	Suburban	Body	Assist Step Controller																																																									
K	2008	Suburban	Body	Body Control Module																																																									
K	2008	Suburban	Body	Body Control Module (aux.)																																																									
K	2008	Suburban	Body	Digital Radio Receiver																																																									
K	2008	Suburban	Body	Driver Door Switch																																																									
K	2008	Suburban	Body	HVAC Control Module Auto																																																									
K	2008	Suburban	Body	HVAC Control Module Manual																																																									
K	2008	Suburban	Body	Instrument Panel Cluster																																																									
K	2008	Suburban	Body	Lift Gate Module																																																									
K	2008	Suburban	Body	Memory Seat Module																																																									
K	2008	Suburban	Body	Park Assist Module																																																									
K	2008	Suburban	Body	Passenger Door Switch																																																									
K	2008	Suburban	Body	Passenger Presence System																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2008	Suburban	Body	Radio																																																										
K	2008	Suburban	Body	Rear Heated Seat Module																																																										
K	2008	Suburban	Body	Rear HVAC/RSA																																																										
K	2008	Suburban	Body	Rollover Sensor																																																										
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2008	Suburban	Body	Theft Deterrent Module																									V	V	V	V																														
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Silverado	Chassis	Electronic Suspension Control																																																										
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																										
K	2008	Silverado	Body	Amplifier (Bose)																																																										
K	2008	Silverado	Body	Body Control Module																																																										
K	2008	Silverado	Body	Body Control Module (aux.)																																																										
K	2008	Silverado	Body	Digital Radio Receiver																																																										
K	2008	Silverado	Body	Driver Door Switch																																																										
K	2008	Silverado	Body	HVAC Control Module Auto																																																										
K	2008	Silverado	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2008	Silverado	Body	Instrument Panel Cluster																																																										
K	2008	Silverado	Body	Memory Seat Module																																																										
K	2008	Silverado	Body	Park Assist Module																																																										
K	2008	Silverado	Body	Passenger Door Switch																																																										
K	2008	Silverado	Body	Passenger Presence System																																																										
K	2008	Silverado	Body	Radio																																																										
K	2008	Silverado	Body	Rear Heated Seat Module																																																										
K	2008	Silverado	Body	Rear HVAC/RSA																																																										
K	2008	Silverado	Body	Rollover Sensor																																																										
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2008	Silverado	Body	Theft Deterrent Module																										V	V	V	V																														
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2008	Tahoe	Body	Amplifier (Bose)																																																										
K	2008	Tahoe	Body	Assist Step Controller																																																										
K	2008	Tahoe	Body	Body Control Module																																																										
K	2008	Tahoe	Body	Body Control Module (aux.)																																																										
K	2008	Tahoe	Body	Digital Radio Receiver																																																										
K	2008	Tahoe	Body	Driver Door Switch																																																										
K	2008	Tahoe	Body	HVAC Control Module Auto																																																										
K	2008	Tahoe	Body	HVAC Control Module Manual																																																										
K	2008	Tahoe	Body	Instrument Panel Cluster																																																										
K	2008	Tahoe	Body	Lift Gate Module																																																										
K	2008	Tahoe	Body	Memory Seat Module																																																										
K	2008	Tahoe	Body	Park Assist Module																																																										
K	2008	Tahoe	Body	Passenger Door Switch																																																										
K	2008	Tahoe	Body	Passenger Presence System																																																										
K	2008	Tahoe	Body	Radio																																																										
K	2008	Tahoe	Body	Rear Heated Seat Module																																																										
K	2008	Tahoe	Body	Rear HVAC/RSA																																																										
K	2008	Tahoe	Body	Rollover Sensor																																																										
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2008	Tahoe	Body	Theft Deterrent Module																										V	V	V	V																														
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2008	Tahoe Hybrid	Body	Body Control Module																																																										
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2008	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2008	Tahoe Hybrid	Body	Memory Seat Module																																																										
K	2008	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2008	Tahoe Hybrid	Body	Radio																																																										
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																										
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																									V	V	V	V																														
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																										
K	2009	Avalanche	Body	Amplifier (Bose)																																																										
K	2009	Avalanche	Body	Assist Step Controller																																																										
K	2009	Avalanche	Body	Body Control Module																																																										
K	2009	Avalanche	Body	Body Control Module (aux.)																																																										
K	2009	Avalanche	Body	Digital Radio Receiver																																																										
K	2009	Avalanche	Body	Driver Door Switch																																																										
K	2009	Avalanche	Body	HVAC Control Module Auto																																																										
K	2009	Avalanche	Body	HVAC Control Module Manual																																																										
K	2009	Avalanche	Body	Instrument Panel Cluster																																																										
K	2009	Avalanche	Body	Memory Seat Module																																																										
K	2009	Avalanche	Body	Park Assist Module																																																										
K	2009	Avalanche	Body	Passenger Door Switch																																																										
K	2009	Avalanche	Body	Passenger Presence System																																																										
K	2009	Avalanche	Body	Radio																																																										
K	2009	Avalanche	Body	Rear Heated Seat Module																																																										
K	2009	Avalanche	Body	Rear HVAC/RSA																																																										
K	2009	Avalanche	Body	Rollover Sensor																																																										
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2009	Avalanche	Body	Theft Deterrent Module																									V	V	V	V																														
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																										
K	2009	Cheyenne	Body	Amplifier (Bose)																																																										
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2009	Cheyenne	Body	Digital Radio Receiver																																																										
K	2009	Cheyenne	Body	Driver Door Switch																																																										
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2009	Cheyenne	Body	Park Assist Module																																																										
K	2009	Cheyenne	Body	Passenger Door Switch																																																										
K	2009	Cheyenne	Body	Passenger Presence System																																																										
K	2009	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2009	Cheyenne	Body	Rollover Sensor																																																										
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2009	Cheyenne	Body	Theft Deterrent Module																									V	V	V	V																														
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2009	Suburban	Chassis	Electronic Suspension Control																																																									
K	2009	Suburban	Chassis	Trailer Brake Control Module																																																									
K	2009	Suburban	Body	Amplifier (Bose)																																																									
K	2009	Suburban	Body	Assist Step Controller																																																									
K	2009	Suburban	Body	Body Control Module																																																								
K	2009	Suburban	Body	Body Control Module (aux.)																																																									
K	2009	Suburban	Body	Digital Radio Receiver																																																									
K	2009	Suburban	Body	Driver Door Switch																																																									
K	2009	Suburban	Body	HVAC Control Module Auto																																																									
K	2009	Suburban	Body	HVAC Control Module Manual																																																									
K	2009	Suburban	Body	Instrument Panel Cluster																																																									
K	2009	Suburban	Body	Left Side Object Detection Module																																																									
K	2009	Suburban	Body	Lift Gate Module																																																									
K	2009	Suburban	Body	Memory Seat Module																																																									
K	2009	Suburban	Body	Park Assist Module																																																									
K	2009	Suburban	Body	Passenger Door Switch																																																									
K	2009	Suburban	Body	Passenger Presence System																																																									
K	2009	Suburban	Body	Radio																																																									
K	2009	Suburban	Body	Rear Heated Seat Module																																																									
K	2009	Suburban	Body	Rear HVAC/RSA																																																									
K	2009	Suburban	Body	Right Side Object Detection Module																																																									
K	2009	Suburban	Body	Rollover Sensor																																																									
K	2009	Suburban	Body	Supplemental Inflatable Restraint																																																									
K	2009	Suburban	Body	Theft Deterrent Module																										V	V	V	V																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																									
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																									
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																									
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																									
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																									
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																									
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																									
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																									
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																									
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																									
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																									
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
K	2009	Silverado	Chassis	Electronic Suspension Control																																																									
K	2009	Silverado	Chassis	Trailer Brake Control Module																																																									
K	2009	Silverado	Body	Amplifier (Bose)																																																									
K	2009	Silverado	Body	Body Control Module																																																								
K	2009	Silverado	Body	Body Control Module (aux.)																																																								
K	2009	Silverado	Body	Digital Radio Receiver																																																								
K	2009	Silverado	Body	Driver Door Switch																																																								
K	2009	Silverado	Body	HVAC Control Module Auto																																																								
K	2009	Silverado	Body	HVAC Control Module Manual																																																								
K	2009	Silverado	Body	Instrument Panel Cluster																																																								
K	2009	Silverado	Body	Memory Seat Module																																																								
K	2009	Silverado	Body	Park Assist Module																																																								
K	2009	Silverado	Body	Passenger Door Switch																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2009	Silverado	Body	Passenger Presence System																																																										
K	2009	Silverado	Body	Radio																																																										
K	2009	Silverado	Body	Rear Heated Seat Module																																																										
K	2009	Silverado	Body	Rear HVAC/RSA																																																										
K	2009	Silverado	Body	Rollover Sensor																																																										
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2009	Silverado	Body	Theft Deterrent Module																										V	V	V	V																														
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Silverado Hybrid	Body	Body Control Module																																																										
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2009	Silverado Hybrid	Body	HVAC Control Module																																																										
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Silverado Hybrid	Body	Memory Seat Module																																																										
K	2009	Silverado Hybrid	Body	Park Assist Module																																																										
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2009	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2009	Silverado Hybrid	Body	Radio																																																										
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																										
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																										V	V	V	V																														
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																									
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																									
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																									
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
K	2009	Tahoe	Chassis	Electronic Brake Control Module																																																									
K	2009	Tahoe	Chassis	Electronic Suspension Control																																																									
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																																									
K	2009	Tahoe	Body	Amplifier (Bose)																																																									
K	2009	Tahoe	Body	Assist Step Controller																																																									
K	2009	Tahoe	Body	Body Control Module																																																									
K	2009	Tahoe	Body	Body Control Module (aux.)																																																									
K	2009	Tahoe	Body	Digital Radio Receiver																																																									
K	2009	Tahoe	Body	Driver Door Switch																																																									
K	2009	Tahoe	Body	HVAC Control Module Auto																																																									
K	2009	Tahoe	Body	HVAC Control Module Manual																																																									
K	2009	Tahoe	Body	Instrument Panel Cluster																																																									
K	2009	Tahoe	Body	Left Side Object Detection Module																																																									
K	2009	Tahoe	Body	Lift Gate Module																																																									
K	2009	Tahoe	Body	Memory Seat Module																																																									
K	2009	Tahoe	Body	Park Assist Module																																																									
K	2009	Tahoe	Body	Passenger Door Switch																																																									
K	2009	Tahoe	Body	Passenger Presence System																																																									
K	2009	Tahoe	Body	Radio																																																									
K	2009	Tahoe	Body	Rear Heated Seat Module																																																									
K	2009	Tahoe	Body	Rear HVAC/RSA																																																									
K	2009	Tahoe	Body	Right Side Object Detection Module																																																									
K	2009	Tahoe	Body	Rollover Sensor																																																									
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																									
K	2009	Tahoe	Body	Theft Deterrent Module																										V	V	V	V																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																									
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																									
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
K	2009	Tahoe Hybrid	Body	Body Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																																									
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																																									
K	2009	Tahoe Hybrid	Body	HVAC Control Module																																																									
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																									
K	2009	Tahoe Hybrid	Body	Park Assist Module																																																									
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																									
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																																									
K	2009	Tahoe Hybrid	Body	Radio																																																									
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																									
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																									
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																									
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																										V	V	V	V																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																									
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																									
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																									
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																									
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
K	2010	Avalanche	Chassis	Electronic Brake Control Module																																																									
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																									
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Avalanche	Body	Amplifier (Bose)																																																									
K	2010	Avalanche	Body	Assist Step Controller																																																									
K	2010	Avalanche	Body	Body Control Module																																																									
K	2010	Avalanche	Body	Body Control Module (aux.)																																																									
K	2010	Avalanche	Body	Digital Radio Receiver																																																									
K	2010	Avalanche	Body	Driver Door Switch																																																									
K	2010	Avalanche	Body	HVAC Control Module Auto																																																									
K	2010	Avalanche	Body	HVAC Control Module Manual																																																									
K	2010	Avalanche	Body	Instrument Panel Cluster																																																									
K	2010	Avalanche	Body	Memory Seat Module																																																									
K	2010	Avalanche	Body	Park Assist Module																																																									
K	2010	Avalanche	Body	Passenger Door Switch																																																									
K	2010	Avalanche	Body	Passenger Presence System																																																									
K	2010	Avalanche	Body	Radio																																																									
K	2010	Avalanche	Body	Rear Heated Seat Module																																																									
K	2010	Avalanche	Body	Rear HVAC/RSA																																																									
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																									
K	2010	Avalanche	Body	Theft Deterrent Module																										V	V	V	V																												
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Cheyenne	Body	Amplifier (Bose)																																																										
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2010	Cheyenne	Body	Digital Radio Receiver																																																										
K	2010	Cheyenne	Body	Driver Door Switch																																																										
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2010	Cheyenne	Body	Park Assist Module																																																										
K	2010	Cheyenne	Body	Passenger Door Switch																																																										
K	2010	Cheyenne	Body	Passenger Presence System																																																										
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2010	Cheyenne	Body	Theft Deterrent Module																										V	V	V	V																													
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2010	Suburban	Chassis	Electronic Suspension Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Body	Amplifier (Bose)																																																										
K	2010	Suburban	Body	Assist Step Controller																																																										
K	2010	Suburban	Body	Body Control Module																																																										
K	2010	Suburban	Body	Body Control Module (aux.)																																																										
K	2010	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2010	Suburban	Body	Driver Door Switch																																																										
K	2010	Suburban	Body	HVAC Control Module Auto																																																										
K	2010	Suburban	Body	HVAC Control Module Manual																																																										
K	2010	Suburban	Body	Instrument Panel Cluster																																																										
K	2010	Suburban	Body	Left Side Object Detection Module																																																										
K	2010	Suburban	Body	Lift Gate Module																																																										
K	2010	Suburban	Body	Memory Seat Module																																																										
K	2010	Suburban	Body	Park Assist Module																																																										
K	2010	Suburban	Body	Passenger Door Switch																																																										
K	2010	Suburban	Body	Passenger Presence System																																																										
K	2010	Suburban	Body	Radio																																																										
K	2010	Suburban	Body	Rear Heated Seat Module																																																										
K	2010	Suburban	Body	Rear HVAC/RSA																																																										
K	2010	Suburban	Body	Right Side Object Detection Module																																																										
K	2010	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2010	Suburban	Body	Theft Deterrent Module																									V	V	V	V																														
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																										
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
K	2010	Silverado	Chassis	Electronic Suspension Control																																																										
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2010	Silverado	Body	Amplifier (Bose)																																																										
K	2010	Silverado	Body	Body Control Module																																																										
K	2010	Silverado	Body	Body Control Module (aux.)																																																										
K	2010	Silverado	Body	Digital Radio Receiver																																																										
K	2010	Silverado	Body	Driver Door Switch																																																										
K	2010	Silverado	Body	HVAC Control Module Auto																																																										
K	2010	Silverado	Body	HVAC Control Module Manual																																																										
K	2010	Silverado	Body	Instrument Panel Cluster																																																										
K	2010	Silverado	Body	Memory Seat Module																																																										
K	2010	Silverado	Body	Park Assist Module																																																										
K	2010	Silverado	Body	Passenger Door Switch																																																										
K	2010	Silverado	Body	Passenger Presence System																																																										
K	2010	Silverado	Body	Radio																																																										
K	2010	Silverado	Body	Rear Heated Seat Module																																																										
K	2010	Silverado	Body	Rear HVAC/RSA																																																										
K	2010	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2010	Silverado	Body	Theft Deterrent Module																										V	V	V	V																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																V										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Silverado Hybrid	Body	Body Control Module																																																										
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2010	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2010	Silverado Hybrid	Body	HVAC Control Module																																																										
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Silverado Hybrid	Body	Park Assist Module																																																										
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2010	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2010	Silverado Hybrid	Body	Radio																																																										
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																										V	V	V	V																											
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2010	Tahoe	Chassis	Electronic Brake Control Module																																																								
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																								
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Tahoe	Body	Amplifier (Bose)																																																								
K	2010	Tahoe	Body	Assist Step Controller																																																								
K	2010	Tahoe	Body	Body Control Module																																																								
K	2010	Tahoe	Body	Body Control Module (aux.)																																																								
K	2010	Tahoe	Body	Digital Radio Receiver																																																								
K	2010	Tahoe	Body	Driver Door Switch																																																								
K	2010	Tahoe	Body	HVAC Control Module Auto																																																								
K	2010	Tahoe	Body	HVAC Control Module Manual																																																								
K	2010	Tahoe	Body	Instrument Panel Cluster																																																								
K	2010	Tahoe	Body	Left Side Object Detection Module																																																								
K	2010	Tahoe	Body	Lift Gate Module																																																								
K	2010	Tahoe	Body	Memory Seat Module																																																								
K	2010	Tahoe	Body	Park Assist Module																																																								
K	2010	Tahoe	Body	Passenger Door Switch																																																								
K	2010	Tahoe	Body	Passenger Presence System																																																								
K	2010	Tahoe	Body	Radio																																																								
K	2010	Tahoe	Body	Rear Heated Seat Module																																																								
K	2010	Tahoe	Body	Rear HVAC/RSA																																																								
K	2010	Tahoe	Body	Right Side Object Detection Module																																																								
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																								
K	2010	Tahoe	Body	Theft Deterrent Module																										V	V	V	V																											
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																												V											
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
K	2010	Tahoe Hybrid	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																																									
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																																									
K	2010	Tahoe Hybrid	Body	HVAC Control Module																																																									
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																									
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																																									
K	2010	Tahoe Hybrid	Body	Park Assist Module																																																									
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																									
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																																									
K	2010	Tahoe Hybrid	Body	Radio																																																									
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																									
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																									
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																										V	V	V	V																												
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																	V																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																	V																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module																																																									
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module																																																									
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																	V																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																	V																								
K	2011	Avalanche	Chassis	Electronic Brake Control Module																																																									
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																									
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
K	2011	Avalanche	Body	Amplifier (Bose)																																																									
K	2011	Avalanche	Body	Assist Step Controller																																																									
K	2011	Avalanche	Body	Body Control Module																																																									
K	2011	Avalanche	Body	Body Control Module (aux.)																																																									
K	2011	Avalanche	Body	Digital Radio Receiver																																																									
K	2011	Avalanche	Body	Driver Door Switch																																																									
K	2011	Avalanche	Body	HVAC Control Module Auto																																																									
K	2011	Avalanche	Body	HVAC Control Module Manual																																																									
K	2011	Avalanche	Body	Instrument Panel Cluster																																																									
K	2011	Avalanche	Body	Memory Seat Module																																																									
K	2011	Avalanche	Body	Park Assist Module																																																									
K	2011	Avalanche	Body	Passenger Door Switch																																																									
K	2011	Avalanche	Body	Passenger Presence System																																																									
K	2011	Avalanche	Body	Radio																																																									
K	2011	Avalanche	Body	Rear Heated Seat Module																																																									
K	2011	Avalanche	Body	Rear HVAC/RSA																																																									
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																									
K	2011	Avalanche	Body	Theft Deterrent Module																										V	V	V	V																												
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																V																								
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																							
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																							
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																						
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																V																							
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																						
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																						
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																					
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																					
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																					
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																					
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																					
K	2011	Cheyenne	Body	Amplifier (Bose)																																																					
K	2011	Cheyenne	Body	Body Control Module																																																					
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																					
K	2011	Cheyenne	Body	Digital Radio Receiver																																																					
K	2011	Cheyenne	Body	Driver Door Switch																																																					
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																					
K	2011	Cheyenne	Body	Park Assist Module																																																					
K	2011	Cheyenne	Body	Passenger Door Switch																																																					
K	2011	Cheyenne	Body	Passenger Presence System																																																					
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																					
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																					
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																					
K	2011	Cheyenne	Body	Theft Deterrent Module																										V	V	V	V																									
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																					
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																					
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																V																							
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																V																							
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																					
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																					
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																					
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																V																							
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																V																							
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																					
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																					
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																V																							
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																					
K	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																					
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																					
K	2011	Suburban	Chassis	Electronic Suspension Control																																																					
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																					
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																					
K	2011	Suburban	Body	Amplifier (Bose)																																																					
K	2011	Suburban	Body	Assist Step Controller																																																					
K	2011	Suburban	Body	Body Control Module																																																					
K	2011	Suburban	Body	Body Control Module (aux.)																																																					
K	2011	Suburban	Body	Digital Radio Receiver																																																					
K	2011	Suburban	Body	Driver Door Switch																																																					
K	2011	Suburban	Body	HVAC Control Module Auto																																																					
K	2011	Suburban	Body	HVAC Control Module Manual																																																					

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2011	Suburban	Body	Instrument Panel Cluster																																																										
K	2011	Suburban	Body	Left Side Object Detection Module																																																										
K	2011	Suburban	Body	Lift Gate Module																																																										
K	2011	Suburban	Body	Memory Seat Module																																																										
K	2011	Suburban	Body	Park Assist Module																																																										
K	2011	Suburban	Body	Passenger Door Switch																																																										
K	2011	Suburban	Body	Passenger Presence System																																																										
K	2011	Suburban	Body	Radio																																																										
K	2011	Suburban	Body	Rear Heated Seat Module																																																										
K	2011	Suburban	Body	Rear HVAC/RSA																																																										
K	2011	Suburban	Body	Right Side Object Detection Module																																																										
K	2011	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2011	Suburban	Body	Theft Deterrent Module																									V	V	V	V																														
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																	V																										
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																	V																										
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module																																																										
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module																																																										
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																	V																										
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																	V																										
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																										
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																	V																										
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																	V																										
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module										V																																																
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																	V																										
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																																
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																	V																										
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
K	2011	Silverado	Chassis	Electronic Suspension Control																																																										
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2011	Silverado	Body	Amplifier (Bose)																																																										
K	2011	Silverado	Body	Body Control Module																																																										
K	2011	Silverado	Body	Body Control Module (aux.)																																																										
K	2011	Silverado	Body	Digital Radio Receiver																																																										
K	2011	Silverado	Body	Driver Door Switch																																																										
K	2011	Silverado	Body	HVAC Control Module Auto																																																										
K	2011	Silverado	Body	HVAC Control Module Manual																																																										
K	2011	Silverado	Body	Instrument Panel Cluster																																																										
K	2011	Silverado	Body	Memory Seat Module																																																										
K	2011	Silverado	Body	Park Assist Module																																																										
K	2011	Silverado	Body	Passenger Door Switch																																																										
K	2011	Silverado	Body	Passenger Presence System																																																										
K	2011	Silverado	Body	Radio																																																										
K	2011	Silverado	Body	Rear Heated Seat Module																																																										
K	2011	Silverado	Body	Rear HVAC/RSA																																																										
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2011	Silverado	Body	Theft Deterrent Module																										V	V	V	V																													
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																V									
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																V																										
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2011	Silverado Hybrid	Body	Body Control Module																																																										
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2011	Silverado Hybrid	Body	HVAC Control Module																																																										
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2011	Silverado Hybrid	Body	Park Assist Module																																																										
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2011	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2011	Silverado Hybrid	Body	Radio																																																										
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																										V	V	V	V																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																	V																								
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																	V																								
K	2011	Tahoe	Chassis	Electronic Brake Control Module																																																									
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																									
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
K	2011	Tahoe	Body	Amplifier (Bose)																																																									
K	2011	Tahoe	Body	Assist Step Controller																																																									
K	2011	Tahoe	Body	Body Control Module																																																									
K	2011	Tahoe	Body	Body Control Module (aux.)																																																									
K	2011	Tahoe	Body	Digital Radio Receiver																																																									
K	2011	Tahoe	Body	Driver Door Switch																																																									
K	2011	Tahoe	Body	HVAC Control Module Auto																																																									
K	2011	Tahoe	Body	HVAC Control Module Manual																																																									
K	2011	Tahoe	Body	Instrument Panel Cluster																																																									
K	2011	Tahoe	Body	Left Side Object Detection Module																																																									
K	2011	Tahoe	Body	Lift Gate Module																																																									
K	2011	Tahoe	Body	Memory Seat Module																																																									
K	2011	Tahoe	Body	Park Assist Module																																																									
K	2011	Tahoe	Body	Passenger Door Switch																																																									
K	2011	Tahoe	Body	Passenger Presence System																																																									
K	2011	Tahoe	Body	Radio																																																									
K	2011	Tahoe	Body	Rear Heated Seat Module																																																									
K	2011	Tahoe	Body	Rear HVAC/RSA																																																									
K	2011	Tahoe	Body	Right Side Object Detection Module																																																									
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																									
K	2011	Tahoe	Body	Theft Deterrent Module																										V	V	V	V																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																	V																								
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
K	2011	Tahoe Hybrid	Body	Body Control Module																																																									
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																																									
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																																									
K	2011	Tahoe Hybrid	Body	HVAC Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																									
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																																									
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																									
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																									
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																																									
K	2011	Tahoe Hybrid	Body	Radio																																																									
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																									
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																									
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																									V	V	V	V																													
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																V																									
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																V																									
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																V																									
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																V																									
K	2012	Avalanche	Chassis	Electronic Brake Control Module																																																									
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																									
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Avalanche	Body	Amplifier (Bose)																																																									
K	2012	Avalanche	Body	Assist Step Controller																																																									
K	2012	Avalanche	Body	Body Control Module																																																									
K	2012	Avalanche	Body	Body Control Module (aux.)																																																									
K	2012	Avalanche	Body	Digital Radio Receiver																																																									
K	2012	Avalanche	Body	Driver Door Switch																																																									
K	2012	Avalanche	Body	HVAC Control Module Auto																																																									
K	2012	Avalanche	Body	HVAC Control Module Manual																																																									
K	2012	Avalanche	Body	Instrument Panel Cluster																																																									
K	2012	Avalanche	Body	Memory Seat Module																																																									
K	2012	Avalanche	Body	Navigation Radio																																																									
K	2012	Avalanche	Body	Park Assist Module																																																									
K	2012	Avalanche	Body	Passenger Door Switch																																																									
K	2012	Avalanche	Body	Passenger Presence System																																																									
K	2012	Avalanche	Body	Radio																																																									
K	2012	Avalanche	Body	Rear Heated Seat Module																																																									
K	2012	Avalanche	Body	Rear HVAC/RSA																																																									
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																									
K	2012	Avalanche	Body	Theft Deterrent Module																									V	V	V	V																													
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																									
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																									
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																V																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																V																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Cheyenne	Body	Amplifier (Bose)																																																										
K	2012	Cheyenne	Body	Body Control Module																																																										
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2012	Cheyenne	Body	Digital Radio Receiver																																																										
K	2012	Cheyenne	Body	Driver Door Switch																																																										
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2012	Cheyenne	Body	Park Assist Module																																																										
K	2012	Cheyenne	Body	Passenger Door Switch																																																										
K	2012	Cheyenne	Body	Passenger Presence System																																																										
K	2012	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2012	Cheyenne	Body	Theft Deterrent Module																										V	V	V	V																													
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																V																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																V																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																V																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																V																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																V																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2012	Suburban	Chassis	Electronic Suspension Control																																																										
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Suburban	Body	Amplifier (Bose)																																																										
K	2012	Suburban	Body	Assist Step Controller																																																										
K	2012	Suburban	Body	Body Control Module																																																										
K	2012	Suburban	Body	Body Control Module (aux.)																																																										
K	2012	Suburban	Body	Digital Radio Receiver																																																										
K	2012	Suburban	Body	Driver Door Switch																																																										
K	2012	Suburban	Body	HVAC Control Module Auto																																																										
K	2012	Suburban	Body	HVAC Control Module Manual																																																										
K	2012	Suburban	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2012	Suburban	Body	Left Side Object Detection Module																																																										
K	2012	Suburban	Body	Lift Gate Module																																																										
K	2012	Suburban	Body	Memory Seat Module																																																										
K	2012	Suburban	Body	Navigation Radio																																																										
K	2012	Suburban	Body	Park Assist Module																																																										
K	2012	Suburban	Body	Passenger Door Switch																																																										
K	2012	Suburban	Body	Passenger Presence System																																																										
K	2012	Suburban	Body	Radio																																																										
K	2012	Suburban	Body	Rear Heated Seat Module																																																										
K	2012	Suburban	Body	Rear HVAC/RSA																																																										
K	2012	Suburban	Body	Right Side Object Detection Module																																																										
K	2012	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2012	Suburban	Body	Theft Deterrent Module																									V	V	V	V																														
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																V																											
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																V																											
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																V																											
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																V																											
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																V																											
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																V																											
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module										V																																																
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																V																											
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																																
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																V																											
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2012	Silverado	Chassis	Electronic Suspension Control																																																									
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
K	2012	Silverado	Body	Amplifier (Bose)																																																									
K	2012	Silverado	Body	Body Control Module																																																									
K	2012	Silverado	Body	Body Control Module (aux.)																																																									
K	2012	Silverado	Body	Digital Radio Receiver																																																									
K	2012	Silverado	Body	Driver Door Switch																																																									
K	2012	Silverado	Body	HVAC Control Module Auto																																																									
K	2012	Silverado	Body	HVAC Control Module Manual																																																									
K	2012	Silverado	Body	Instrument Panel Cluster																																																									
K	2012	Silverado	Body	Memory Seat Module																																																									
K	2012	Silverado	Body	Navigation Radio																																																									
K	2012	Silverado	Body	Park Assist Module																																																									
K	2012	Silverado	Body	Passenger Door Switch																																																									
K	2012	Silverado	Body	Passenger Presence System																																																									
K	2012	Silverado	Body	Radio																																																									
K	2012	Silverado	Body	Rear Heated Seat Module																																																									
K	2012	Silverado	Body	Rear HVAC/RSA																																																									
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																																									
K	2012	Silverado	Body	Theft Deterrent Module																										V	V	V	V																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																									
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																													V												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																	V																								
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																									
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																									
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																									
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																									
K	2012	Silverado Hybrid	Body	Body Control Module																																																									
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																									
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																									
K	2012	Silverado Hybrid	Body	Driver Door Switch																																																									
K	2012	Silverado Hybrid	Body	Heated Seat Module																																																									
K	2012	Silverado Hybrid	Body	HVAC Control Module																																																									
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																									
K	2012	Silverado Hybrid	Body	Navigation Radio																																																									
K	2012	Silverado Hybrid	Body	Park Assist Module																																																									
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																																									
K	2012	Silverado Hybrid	Body	Passenger Presence System																																																									
K	2012	Silverado Hybrid	Body	Radio																																																									
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																									
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																									
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																									
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2012	Silverado Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																	V																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																	V																										
K	2012	Tahoe	Chassis	EBCM with Trailer Brake																																																										
K	2012	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Tahoe	Body	Amplifier (Bose)																																																										
K	2012	Tahoe	Body	Assist Step Controller																																																										
K	2012	Tahoe	Body	Body Control Module																																																										
K	2012	Tahoe	Body	Body Control Module (aux.)																																																										
K	2012	Tahoe	Body	Digital Radio Receiver																																																										
K	2012	Tahoe	Body	Driver Door Switch																																																										
K	2012	Tahoe	Body	HVAC Control Module Auto																																																										
K	2012	Tahoe	Body	HVAC Control Module Manual																																																										
K	2012	Tahoe	Body	Instrument Panel Cluster																																																										
K	2012	Tahoe	Body	Left Side Object Detection Module																																																										
K	2012	Tahoe	Body	Lift Gate Module																																																										
K	2012	Tahoe	Body	Memory Seat Module																																																										
K	2012	Tahoe	Body	Navigation Radio																																																										
K	2012	Tahoe	Body	Park Assist Module																																																										
K	2012	Tahoe	Body	Passenger Door Switch																																																										
K	2012	Tahoe	Body	Passenger Presence System																																																										
K	2012	Tahoe	Body	Radio																																																										
K	2012	Tahoe	Body	Rear Heated Seat Module																																																										
K	2012	Tahoe	Body	Rear HVAC/RSA																																																										
K	2012	Tahoe	Body	Right Side Object Detection Module																																																										
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2012	Tahoe	Body	Theft Deterrent Module																										V	V	V	V																													
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																	V																										
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2012	Tahoe Hybrid	Body	Body Control Module																																																										
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2012	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																										
K	2012	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2012	Tahoe Hybrid	Body	Radio																																																										
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																V																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																V																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																V																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																V																										
K	2013	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Avalanche	Body	Amplifier (Bose)																																																										
K	2013	Avalanche	Body	Assist Step Controller																																																										
K	2013	Avalanche	Body	Body Control Module																																																										
K	2013	Avalanche	Body	Body Control Module (aux.)																																																										
K	2013	Avalanche	Body	Digital Radio Receiver																																																										
K	2013	Avalanche	Body	Driver Door Switch																																																										
K	2013	Avalanche	Body	HVAC Control Module Auto																																																										
K	2013	Avalanche	Body	HVAC Control Module Manual																																																										
K	2013	Avalanche	Body	Instrument Panel Cluster																																																										
K	2013	Avalanche	Body	Memory Seat Module																																																										
K	2013	Avalanche	Body	Navigation Radio																																																										
K	2013	Avalanche	Body	Park Assist Module																																																										
K	2013	Avalanche	Body	Passenger Door Switch																																																										
K	2013	Avalanche	Body	Passenger Presence System																																																										
K	2013	Avalanche	Body	Radio																																																										
K	2013	Avalanche	Body	Rear Heated Seat Module																																																										
K	2013	Avalanche	Body	Rear HVAC/RSA																																																										
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2013	Avalanche	Body	Theft Deterrent Module																										V	V	V	V																													
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																V																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																V																										
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Cheyenne	Body	Amplifier (Bose)																																																										
K	2013	Cheyenne	Body	Body Control Module																																																										
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2013	Cheyenne	Body	Digital Radio Receiver																																																										
K	2013	Cheyenne	Body	Driver Door Switch																																																										
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2013	Cheyenne	Body	Park Assist Module																																																										
K	2013	Cheyenne	Body	Passenger Door Switch																																																										
K	2013	Cheyenne	Body	Passenger Presence System																																																										
K	2013	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2013	Cheyenne	Body	Theft Deterrent Module																										V	V	V	V																													
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																V																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																V																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																V																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																V																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																V																										
K	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2013	Suburban	Chassis	Electronic Suspension Control																																																										
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Suburban	Body	Amplifier (Bose)																																																										
K	2013	Suburban	Body	Assist Step Controller																																																										
K	2013	Suburban	Body	Body Control Module																																																										
K	2013	Suburban	Body	Body Control Module (aux.)																																																										
K	2013	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2013	Suburban	Body	Driver Door Switch																																																										
K	2013	Suburban	Body	HVAC Control Module Auto																																																										
K	2013	Suburban	Body	HVAC Control Module Manual																																																										
K	2013	Suburban	Body	Instrument Panel Cluster																																																										
K	2013	Suburban	Body	Left Side Object Detection Module																																																										
K	2013	Suburban	Body	Lift Gate Module																																																										
K	2013	Suburban	Body	Memory Seat Module																																																										
K	2013	Suburban	Body	Navigation Radio																																																										
K	2013	Suburban	Body	Park Assist Module																																																										
K	2013	Suburban	Body	Passenger Door Switch																																																										
K	2013	Suburban	Body	Passenger Presence System																																																										
K	2013	Suburban	Body	Radio																																																										
K	2013	Suburban	Body	Rear Heated Seat Module																																																										
K	2013	Suburban	Body	Rear HVAC/RSA																																																										
K	2013	Suburban	Body	Right Side Object Detection Module																																																										
K	2013	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2013	Suburban	Body	Theft Deterrent Module																									V	V	V	V																														
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																V																											
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																V																											
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																V																											
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																V																											
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																										
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																V																											
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																V																											
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																V																											
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module										V																																																
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																V																											
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																									
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
K	2013	Silverado	Chassis	Electronic Suspension Control																																																									
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
K	2013	Silverado	Body	Amplifier (Bose)																																																									
K	2013	Silverado	Body	Body Control Module																																																									
K	2013	Silverado	Body	Body Control Module (aux.)																																																									
K	2013	Silverado	Body	Digital Radio Receiver																																																									
K	2013	Silverado	Body	Driver Door Switch																																																									
K	2013	Silverado	Body	HVAC Control Module Auto																																																									
K	2013	Silverado	Body	HVAC Control Module Manual																																																									
K	2013	Silverado	Body	Instrument Panel Cluster																																																									
K	2013	Silverado	Body	Memory Seat Module																																																									
K	2013	Silverado	Body	Navigation Radio																																																									
K	2013	Silverado	Body	Park Assist Module																																																									
K	2013	Silverado	Body	Passenger Door Switch																																																									
K	2013	Silverado	Body	Passenger Presence System																																																									
K	2013	Silverado	Body	Radio																																																									
K	2013	Silverado	Body	Rear Heated Seat Module																																																									
K	2013	Silverado	Body	Rear HVAC/RSA																																																									
K	2013	Silverado	Body	Supplemental Inflatable Restraint																																																									
K	2013	Silverado	Body	Theft Deterrent Module																										V	V	V	V																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																V																									
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																									
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																									
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																									
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																									
K	2013	Silverado Hybrid	Body	Body Control Module																																																									
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																									
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																									
K	2013	Silverado Hybrid	Body	Driver Door Switch																																																									
K	2013	Silverado Hybrid	Body	Heated Seat Module																																																									
K	2013	Silverado Hybrid	Body	HVAC Control Module																																																									
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																									
K	2013	Silverado Hybrid	Body	Navigation Radio																																																									
K	2013	Silverado Hybrid	Body	Park Assist Module																																																									
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																																									
K	2013	Silverado Hybrid	Body	Passenger Presence System																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2013	Silverado Hybrid	Body	Radio																																																									
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																									
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																									
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																									
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																										V	V	V	V																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																	V																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																	V																								
K	2013	Tahoe	Chassis	Electronic Brake Control Module																																																									
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																									
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Tahoe	Body	Amplifier (Bose)																																																									
K	2013	Tahoe	Body	Assist Step Controller																																																									
K	2013	Tahoe	Body	Body Control Module																																																									
K	2013	Tahoe	Body	Body Control Module (aux.)																																																									
K	2013	Tahoe	Body	Digital Radio Receiver																																																									
K	2013	Tahoe	Body	Driver Door Switch																																																									
K	2013	Tahoe	Body	HVAC Control Module Auto																																																									
K	2013	Tahoe	Body	HVAC Control Module Manual																																																									
K	2013	Tahoe	Body	Instrument Panel Cluster																																																									
K	2013	Tahoe	Body	Left Side Object Detection Module																																																									
K	2013	Tahoe	Body	Lift Gate Module																																																									
K	2013	Tahoe	Body	Memory Seat Module																																																									
K	2013	Tahoe	Body	Navigation Radio																																																									
K	2013	Tahoe	Body	Park Assist Module																																																									
K	2013	Tahoe	Body	Passenger Door Switch																																																									
K	2013	Tahoe	Body	Passenger Presence System																																																									
K	2013	Tahoe	Body	Radio																																																									
K	2013	Tahoe	Body	Rear Heated Seat Module																																																									
K	2013	Tahoe	Body	Rear HVAC/RSA																																																									
K	2013	Tahoe	Body	Right Side Object Detection Module																																																									
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																									
K	2013	Tahoe	Body	Theft Deterrent Module																										V	V	V	V																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																	V																								
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
K	2013	Tahoe Hybrid	Body	Body Control Module																																																											
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																											
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																											
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																																											
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																																											
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																											
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																											
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																																											
K	2013	Tahoe Hybrid	Body	Radio																																																											
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																										V	V	V	V																														
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																										
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																										
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																											
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																											
K	2014	Cheyenne	Chassis	Power Steering Control Module																																																											
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2014	Cheyenne	Body	Body Control Module																																																											
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2014	Cheyenne	Body	Passenger Presence Module																																																											
K	2014	Cheyenne	Body	Instrument Cluster																																																											
K	2014	Cheyenne	Body	Radio Control																																																											
K	2014	Cheyenne	Body	HVAC Control																																																											
K	2014	Cheyenne	Body	Radio																																																											
K	2014	Cheyenne	Body	Amplifier																																																											
K	2014	Cheyenne	Body	Media Disc Player																																																											
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																											
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2014	Cheyenne	Body	HVAC Control Module																																																								
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																								
K	2014	Cheyenne	Body	Parking Assist Control Module																																																								
K	2014	Cheyenne	Body	Frontview Camera Module																																																								
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																								
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																								
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																							
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																							
K	2014	Silverado	Chassis	Electronic Brake Control Module																																																								
K	2014	Silverado	Chassis	Parking Brake Control Module																																																								
K	2014	Silverado	Chassis	Power Steering Control Module																																																								
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2014	Silverado	Body	Body Control Module																																																								
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2014	Silverado	Body	Passenger Presence Module																																																								
K	2014	Silverado	Body	Instrument Cluster																																																								
K	2014	Silverado	Body	Radio Control																																																								
K	2014	Silverado	Body	HVAC Control																																																								
K	2014	Silverado	Body	Radio																																																								
K	2014	Silverado	Body	Amplifier																																																								
K	2014	Silverado	Body	Media Disc Player																																																								
K	2014	Silverado	Body	Human Machine Interface Control Module																																																								
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																								
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																								
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																								
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																								
K	2014	Silverado	Body	Parking Assist Control Module																																																								
K	2014	Silverado	Body	Frontview Camera Module																																																								
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																								
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																								
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																								
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																V	V																							
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																								
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2014	Silverado HD	Chassis	Suspension Control Module																																																										
K	2014	Silverado HD	Body	Body Control Module																																																										
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Silverado HD	Body	Passenger Presence Module																																																										
K	2014	Silverado HD	Body	Instrument Cluster																																																										
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
K	2014	Silverado HD	Body	Base Radio																																																										
K	2014	Silverado HD	Body	Navigation Radio																																																										
K	2014	Silverado HD	Body	Uplevel Radio																																																										
K	2014	Silverado HD	Body	Amplifier																																																										
K	2014	Silverado HD	Body	Rear Audio Control Module																																																										
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																										
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																										
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Silverado HD	Body	Seat Memory Control Module	V	V	V																																																							
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																										
K	2014	Silverado HD	Body	Parking Assist Control Module																																																										
K	2014	Silverado HD	Body	Theft Deterrent Module				V	V																																																					
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																										
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																									
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																									
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																									
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2014	Suburban	Chassis	Parking Brake Control Module																																																										
K	2014	Suburban	Chassis	Suspension Control Module																																																										
K	2014	Suburban	Body	Body Control Module																																																										
K	2014	Suburban	Body	Auxiliary Body Control Module																																																										
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Suburban	Body	Passenger Presence Module																																																										
K	2014	Suburban	Body	Instrument Cluster																																																										
K	2014	Suburban	Body	Base Radio																																																										
K	2014	Suburban	Body	Navigation Radio																																																										
K	2014	Suburban	Body	Uplevel Radio																																																										
K	2014	Suburban	Body	Amplifier																																																										
K	2014	Suburban	Body	Rear Audio Control Module																																																										
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																										
K	2014	Suburban	Body	Personal Audio Link Control Module																																																										
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Suburban	Body	Liftgate Control Module																																											V															
K	2014	Suburban	Body	Seat Memory Control Module	V	V	V																																																							
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																										
K	2014	Suburban	Body	Assist Step Control Module																																																										
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																										
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																										
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																										
K	2014	Suburban	Body	Parking Assist Control Module																																																										
K	2014	Suburban	Body	Theft Deterrent Module				V	V																																																					
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																										
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																										
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																										
K	2014	Tahoe	Chassis	Suspension Control Module																																																										
K	2014	Tahoe	Body	Body Control Module																																																										
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																										
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Tahoe	Body	Passenger Presence Module																																																										
K	2014	Tahoe	Body	Instrument Cluster																																																										
K	2014	Tahoe	Body	Base Radio																																																										
K	2014	Tahoe	Body	Navigation Radio																																																										
K	2014	Tahoe	Body	Uplevel Radio																																																										
K	2014	Tahoe	Body	Amplifier																																																										
K	2014	Tahoe	Body	Rear Audio Control Module																																																										
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																										
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																										
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Tahoe	Body	Liftgate Control Module																																											V															
K	2014	Tahoe	Body	Seat Memory Control Module	V	V	V																																																								
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																										
K	2014	Tahoe	Body	Assist Step Control Module																																																										
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																										
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																										
K	2014	Tahoe	Body	Parking Assist Control Module																																																										
K	2014	Tahoe	Body	Theft Deterrent Module				V	V																																																					
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																									
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																									
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																V	V																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																								
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																									
K	2015	Cheyenne	Chassis	Power Steering Control Module																																																									
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2015	Cheyenne	Chassis	Suspension Control Module																																																									
K	2015	Cheyenne	Body	Body Control Module																																																									
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2015	Cheyenne	Body	Passenger Presence Module																																																									
K	2015	Cheyenne	Body	Instrument Cluster																																																									
K	2015	Cheyenne	Body	Radio Controls																																																									
K	2015	Cheyenne	Body	HVAC Controls																																																									
K	2015	Cheyenne	Body	Radio																																																									
K	2015	Cheyenne	Body	Amplifier																																																									
K	2015	Cheyenne	Body	Media Disc Player																																																									
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																									
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																									
K	2015	Cheyenne	Body	HVAC Control Module																																																									
K	2015	Cheyenne	Body	Parking Assist Control Module																																																									
K	2015	Cheyenne	Body	Frontview Camera Module																																																									
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																									
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																									
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																									
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																									
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																									
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																V	V																									
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																									
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																									
K	2015	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																										
K	2015	Silverado	Chassis	Power Steering Control Module																																																										
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Silverado	Chassis	Suspension Control Module																																																										
K	2015	Silverado	Body	Body Control Module																																																										
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Silverado	Body	Passenger Presence Module																																																										
K	2015	Silverado	Body	Instrument Cluster																																																										
K	2015	Silverado	Body	Radio Controls																																																										
K	2015	Silverado	Body	HVAC Controls																																																										
K	2015	Silverado	Body	Radio																																																										
K	2015	Silverado	Body	Amplifier																																																										
K	2015	Silverado	Body	Media Disc Player																																																										
K	2015	Silverado	Body	Human Machine Interface Control Module																																																										
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																																										
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2015	Silverado	Body	Parking Assist Control Module																																																										
K	2015	Silverado	Body	Frontview Camera Module																																																										
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																									
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																									
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																									
K	2015	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
K	2015	Suburban	Chassis	Parking Brake Control Module																																																										
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2015	Suburban	Chassis	Power Steering Control Module																																																										
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Suburban	Chassis	Suspension Control Module																																																										
K	2015	Suburban	Body	Body Control Module																																																										
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Suburban	Body	Passenger Presence Module																																																										
K	2015	Suburban	Body	Instrument Cluster																																																										
K	2015	Suburban	Body	Radio Controls																																																										
K	2015	Suburban	Body	HVAC Controls																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2015	Suburban	Body	Radio																																																									
K	2015	Suburban	Body	Amplifier																																																									
K	2015	Suburban	Body	Media Disc Player																																																									
K	2015	Suburban	Body	Human Machine Interface Control Module																																																										
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																										
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																										
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2015	Suburban	Body	HVAC Control Module																																																										
K	2015	Suburban	Body	Liftgate Control Module																																					V	V	V	V	V	V																
K	2015	Suburban	Body	Keyless Entry Control Module																																																										
K	2015	Suburban	Body	Assist Step Control Module																																																										
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																										
K	2015	Suburban	Body	Parking Assist Control Module																																																										
K	2015	Suburban	Body	Frontview Camera Module																																																										
K	2015	Suburban	Body	Steering Column Lock Control Module																																																										
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																									
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																									
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																									
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																										
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																										
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																										
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																										
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2015	Tahoe	Chassis	Power Steering Control Module																																																										
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Tahoe	Chassis	Suspension Control Module																																																										
K	2015	Tahoe	Body	Body Control Module																																																										
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Tahoe	Body	Passenger Presence Module																																																										
K	2015	Tahoe	Body	Instrument Cluster																																																										
K	2015	Tahoe	Body	Radio Controls																																																										
K	2015	Tahoe	Body	HVAC Controls																																																										
K	2015	Tahoe	Body	Radio																																																										
K	2015	Tahoe	Body	Amplifier																																																										
K	2015	Tahoe	Body	Media Disc Player																																																										
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																										
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																										
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																										
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2015	Tahoe	Body	HVAC Control Module																																																										
K	2015	Tahoe	Body	Liftgate Control Module																																					V	V	V	V	V	V																
K	2015	Tahoe	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2015	Tahoe	Body	Assist Step Control Module																																																									
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																									
K	2015	Tahoe	Body	Parking Assist Control Module																																																									
K	2015	Tahoe	Body	Frontview Camera Module																																																									
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																									
K	2015	Tahoe	Body	Battery Energy Control Module																																																									
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																															V	V																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																															V	V																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																															V	V																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																															V	V																									
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																									
K	2016	Cheyenne	Chassis	Power Steering Control Module																																																									
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2016	Cheyenne	Chassis	Suspension Control Module																																																									
K	2016	Cheyenne	Body	Body Control Module																																																									
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2016	Cheyenne	Body	Passenger Presence Module																																																									
K	2016	Cheyenne	Body	Instrument Cluster																																																									
K	2016	Cheyenne	Body	Radio Controls																																																									
K	2016	Cheyenne	Body	HVAC Controls																																																									
K	2016	Cheyenne	Body	Radio																																																									
K	2016	Cheyenne	Body	Amplifier																																																									
K	2016	Cheyenne	Body	Media Disc Player																																																									
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																									
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																									
K	2016	Cheyenne	Body	HVAC Control Module																																																									
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																									
K	2016	Cheyenne	Body	Parking Assist Control Module																																																									
K	2016	Cheyenne	Body	Frontview Camera Module																																																									
K	2016	Cheyenne	Body	Frontview Camera Module																																																									
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																														V											
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																														V		V	V		V				V		
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																									
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																V	V																									
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																									
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																									
K	2016	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2016	Silverado	Chassis	Power Steering Control Module																																																										
K	2016	Silverado	Chassis	Power Steering Control Module																																																										
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Silverado	Chassis	Suspension Control Module																																																										
K	2016	Silverado	Body	Body Control Module																																																										
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Silverado	Body	Passenger Presence Module																																																										
K	2016	Silverado	Body	Instrument Cluster																																																										
K	2016	Silverado	Body	Radio Controls																																																										
K	2016	Silverado	Body	HVAC Controls																																																										
K	2016	Silverado	Body	Radio (IO3)																																																										
K	2016	Silverado	Body	Radio (IOB)																																																										
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
K	2016	Silverado	Body	Amplifier																																																										
K	2016	Silverado	Body	Media Disc Player																																																										
K	2016	Silverado	Body	Human Machine Interface Control Module																																																										
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																										
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																										
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																										
K	2016	Silverado	Body	Parking Assist Control Module																																																										
K	2016	Silverado	Body	Frontview Camera Module																																																										
K	2016	Silverado	Body	Frontview Camera Module																																																										
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																									
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																									
K	2016	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
K	2016	Suburban	Chassis	Parking Brake Control Module																																																										
K	2016	Suburban	Chassis	Power Steering Control Module																																																										
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Suburban	Chassis	Suspension Control Module																																																										
K	2016	Suburban	Body	Body Control Module																																																										
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2016	Suburban	Body	Passenger Presence Module																																																									
K	2016	Suburban	Body	Instrument Cluster																																																									
K	2016	Suburban	Body	Radio Controls																																																									
K	2016	Suburban	Body	HVAC Controls																																																									
K	2016	Suburban	Body	Radio																																																									
K	2016	Suburban	Body	Amplifier																																																									
K	2016	Suburban	Body	Media Disc Player																																																									
K	2016	Suburban	Body	Human Machine Interface Control Module																																																										
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																																										
K	2016	Suburban	Body	HVAC Control Module																																																										
K	2016	Suburban	Body	Liftgate Control Module																																						V	V	V	V	V	V															
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																									
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																										
K	2016	Suburban	Body	Keyless Entry Control Module																																																										
K	2016	Suburban	Body	Assist Step Control Module																																																										
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																										
K	2016	Suburban	Body	Parking Assist Control Module																																																										
K	2016	Suburban	Body	Frontview Camera Module																																																										
K	2016	Suburban	Body	Steering Column Lock Control Module																																																										
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																									
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																									
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																																									
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																										
K	2016	Tahoe	Chassis	Power Steering Control Module																																																										
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Tahoe	Chassis	Suspension Control Module																																																										
K	2016	Tahoe	Body	Body Control Module																																																										
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Tahoe	Body	Passenger Presence Module																																																										
K	2016	Tahoe	Body	Instrument Cluster																																																										
K	2016	Tahoe	Body	Radio Controls																																																										
K	2016	Tahoe	Body	HVAC Controls																																																										
K	2016	Tahoe	Body	Radio																																																										
K	2016	Tahoe	Body	Amplifier																																																										
K	2016	Tahoe	Body	Media Disc Player																																																										
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																										
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																										
K	2016	Tahoe	Body	HVAC Control Module																																																										
K	2016	Tahoe	Body	Liftgate Control Module																																						V	V	V	V	V	V															
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																										
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																										
K	2016	Tahoe	Body	Keyless Entry Control Module																																																										
K	2016	Tahoe	Body	Assist Step Control Module																																																										
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2016	Tahoe	Body	Parking Assist Control Module																																																										
K	2016	Tahoe	Body	Frontview Camera Module																																																										
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2004	ALL	Chassis	4WAL 3 Sensor																																																										
L	2004	ALL	Body	Body Control Module												V	V																																												
L	2004	ALL	Body	Instrument Panel Cluster																																																										
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2005	Astro	Chassis	4WAL 3 Sensor																																																										
L	2005	Astro	Body	Body Control Module												V	V																																												
L	2005	Astro	Body	Instrument Panel Cluster																																																										
L	2005	Astro	Body	Supplemental Inflatable Restraint																																																										
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module										V																																																
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																																										
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																																										
L	2005	Equinox	Chassis	Electric Power Steering																																																										
L	2005	Equinox	Body	Body Control Module																																																										
L	2005	Equinox	Body	Instrument Panel Cluster																																																										
L	2005	Equinox	Body	Radio																		V																																								
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module										V																																																
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2006	ALL	Chassis	Traction Control Yes																																																										
L	2006	ALL	Chassis	Traction Control No																																																										
L	2006	ALL	Chassis	Electric Power Steering																																																										
L	2006	ALL	Body	Body Control Module																																																										
L	2006	ALL	Body	Instrument Panel Cluster																																																										
L	2006	ALL	Body	Radio																		V																																								
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module										V																																																
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																																										
L	2007	ALL	Chassis	Power Steering Control Module																																																										
L	2007	ALL	Body	Body Control Module																																																										
L	2007	ALL	Body	Digital Radio Receiver																																																										
L	2007	ALL	Body	Heated Seat Module																																																										
L	2007	ALL	Body	HVAC Control Module																																																										
L	2007	ALL	Body	Instrument Panel Cluster																																																										
L	2007	ALL	Body	Passenger Presence System																																																										
L	2007	ALL	Body	Radio																																																										
L	2007	ALL	Body	Rollover Sensor																																																										
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Body	Theft Deterrent Module																										V	V																																
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2008	Captiva Sport	Body	Body Control Module																																																										
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2008	Captiva Sport	Body	HVAC Control Module Auto																																																										
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																																										
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2008	Captiva Sport	Body	Passenger Presence System																																																										
L	2008	Captiva Sport	Body	Radio																																																										
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																							V	V																																			
L	2008	Captiva Sport	Body	Rollover Sensor																																																										
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2008	Captiva Sport	Body	Theft Deterrent Module																									V	V	V	V																														
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module										V																																																
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2008	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2008	Equinox	Chassis	Power Steering Control Module																																																										
L	2008	Equinox	Body	Body Control Module																																																										
L	2008	Equinox	Body	Digital Radio Receiver																																																										
L	2008	Equinox	Body	Heated Seat Module																																																										
L	2008	Equinox	Body	HVAC Control Module																																																										
L	2008	Equinox	Body	Instrument Panel Cluster																																																										
L	2008	Equinox	Body	Passenger Presence System																																																										
L	2008	Equinox	Body	Radio																																																										
L	2008	Equinox	Body	Rollover Sensor																																																										
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2008	Equinox	Body	Theft Deterrent Module																									V	V																																
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																										
L	2009	Captiva Sport	Body	Body Control Module																																																										
L	2009	Captiva Sport	Body	HVAC Control Module Auto																																																										
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																																										
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2009	Captiva Sport	Body	Passenger Presence System																																																										
L	2009	Captiva Sport	Body	Radio																																																										
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																							V	V																																			
L	2009	Captiva Sport	Body	Rollover Sensor																																																										
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2009	Captiva Sport	Body	Theft Deterrent Module																									V	V	V	V																														
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module										V																																																

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2009	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2009	Equinox	Chassis	Power Steering Control Module																																																										
L	2009	Equinox	Body	Body Control Module																																																										
L	2009	Equinox	Body	Digital Radio Receiver																																																										
L	2009	Equinox	Body	Heated Seat Module																																																										
L	2009	Equinox	Body	HVAC Control Module																																																										
L	2009	Equinox	Body	Instrument Panel Cluster																																																										
L	2009	Equinox	Body	Passenger Presence System																																																										
L	2009	Equinox	Body	Radio																																																										
L	2009	Equinox	Body	Rollover Sensor																																																										
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2009	Equinox	Body	Theft Deterrent Module																										V	V																																
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																										
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																										
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																										
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																										
L	2010	Captiva Sport	Body	Body Control Module																																																										
L	2010	Captiva Sport	Body	HVAC Control Module																																																										
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2010	Captiva Sport	Body	Passenger Presence System																																																										
L	2010	Captiva Sport	Body	Radio																																																										
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																								V	V																																
L	2010	Captiva Sport	Body	Rollover Sensor																																																										
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2010	Captiva Sport	Body	Theft Deterrent Module																										V	V	V	V																												
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																										
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																										
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																										
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2010	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2010	Equinox	Body	Body Control Module																																																										
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2010	Equinox	Body	Passenger Presence Module																																																										
L	2010	Equinox	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2010	Equinox	Body	Radio																																																										
L	2010	Equinox	Body	Multimedia Player Interface Module																																																										
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2010	Equinox	Body	Liftgate Control Module																																																										
L	2010	Equinox	Body	Parking Assist Control Module																																																										
L	2010	Equinox	Body	Frontview Camera Module																																																										
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																																										
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
L	2011	Captiva	Chassis	Electronic Brake Control Module																																																										
L	2011	Captiva	Chassis	Parking Brake Control Module																																																										
L	2011	Captiva	Body	Body Control Module																																																										
L	2011	Captiva	Body	Auxiliary Body Control Module																																																										
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2011	Captiva	Body	Instrument Cluster																																																										
L	2011	Captiva	Body	Headlamp Control Module																																																										
L	2011	Captiva	Body	HVAC Control Module																																																										
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																										
L	2011	Captiva	Body	Parking Assist Control Module																																																										
L	2011	Captiva	Body	Theft Deterrent Module				V	V																																																					
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																																										
L	2011	Captiva Sport	Body	Body Control Module																																																										
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2011	Captiva Sport	Body	HVAC Control Module																																																										
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2011	Captiva Sport	Body	Passenger Presence System																																																										
L	2011	Captiva Sport	Body	Radio																																																										
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																								V	V																																	
L	2011	Captiva Sport	Body	Rollover Sensor																																																										
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2011	Captiva Sport	Body	Theft Deterrent Module																										V	V	V	V																													
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																																											
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																											
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																											
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																											
L	2011	Equinox	Chassis	Electronic Brake Control Module																																																											
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2011	Equinox	Body	Body Control Module																																																										
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2011	Equinox	Body	Passenger Presence Module																																																											
L	2011	Equinox	Body	Instrument Cluster																																																											
L	2011	Equinox	Body	Radio																																																										
L	2011	Equinox	Body	Multimedia Player Interface Module																																																											
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											
L	2011	Equinox	Body	Liftgate Control Module																																																											
L	2011	Equinox	Body	Parking Assist Control Module																																																											
L	2011	Equinox	Body	Frontview Camera Module																																																											
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																																																											
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																											
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																											
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																											
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																											
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																											
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																											
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																									
L	2012	Captiva	Chassis	Electronic Brake Control Module																																																									
L	2012	Captiva	Chassis	Parking Brake Control Module																																																									
L	2012	Captiva	Body	Body Control Module																																																									
L	2012	Captiva	Body	Auxiliary Body Control Module																																																									
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2012	Captiva	Body	Instrument Cluster																																																									
L	2012	Captiva	Body	Headlamp Control Module																																																									
L	2012	Captiva	Body	HVAC Control Module																																																									
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																									
L	2012	Captiva	Body	Parking Assist Control Module																																																									
L	2012	Captiva	Body	Theft Deterrent Module				V	V																																																				
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																									
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																									
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																									
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																									
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																									
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																									
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																									
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																									
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module																																																									
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																																									
L	2012	Captiva Sport	Body	Body Control Module																																																									
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																									
L	2012	Captiva Sport	Body	HVAC Control Module																																																									
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																																									
L	2012	Captiva Sport	Body	Passenger Presence System																																																									
L	2012	Captiva Sport	Body	Radio																																																									
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																								V	V																																
L	2012	Captiva Sport	Body	Rollover Sensor																																																									
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																																																									
L	2012	Captiva Sport	Body	Theft Deterrent Module																										V	V	V	V																												
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																									
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																									
L	2012	Equinox	Chassis	Electronic Brake Control Module																																																									
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2012	Equinox	Body	Body Control Module																																																									
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2012	Equinox	Body	Passenger Presence Module																																																									
L	2012	Equinox	Body	Instrument Cluster																																																									
L	2012	Equinox	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2012	Equinox	Body	Multimedia Player Interface Module																																																											
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											
L	2012	Equinox	Body	Liftgate Control Module																																																											
L	2012	Equinox	Body	Parking Assist Control Module																																																											
L	2012	Equinox	Body	Frontview Camera Module																																																											
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																																											
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																											
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																											
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																											
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																											
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																											
L	2013	Captiva	Chassis	Parking Brake Control Module																																																											
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																											
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																											
L	2013	Captiva	Body	Auxiliary Body Control Module																																																											
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2013	Captiva	Body	Instrument Cluster																																																											
L	2013	Captiva	Body	Headlamp Control Module																																																											
L	2013	Captiva	Body	HVAC Control Module																																																											
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)				V	V	V	V																																																				
L	2013	Captiva	Body	Theft Deterrent Module				V	V																																																						
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																											
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																											
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																											
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																											
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																											
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																											
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																																											
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																											
L	2013	Captiva Sport	Body	Body Control Module																																																											
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																											
L	2013	Captiva Sport	Body	Heated Seat Module																																																											
L	2013	Captiva Sport	Body	HVAC Control Module																																																											
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2013	Captiva Sport	Body	Park Assist Module																																																										
L	2013	Captiva Sport	Body	Passenger Presence System																																																										
L	2013	Captiva Sport	Body	Radio																																																										
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																							V	V																																		
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																										
L	2013	Captiva Sport	Body	Theft Deterrent Module																									V	V	V	V																														
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2013	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2013	Equinox	Chassis	Power Steering Control Module																																																										
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2013	Equinox	Body	Passenger Presence Module																																																										
L	2013	Equinox	Body	Instrument Cluster																																																										
L	2013	Equinox	Body	Radio																																																										
L	2013	Equinox	Body	Rear Audio Control Module																																																										
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2013	Equinox	Body	Liftgate Control Module																																																										
L	2013	Equinox	Body	Front Seat Heating Control Module																																																										
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2013	Equinox	Body	Parking Assist Control Module																																																										
L	2013	Equinox	Body	Frontview Camera Module																																																										
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2014	Captiva (3GN)	Body	Body Control Module																																																										
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																										
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2014	Captiva (3GN)	Body	Radio																																																										
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																										
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																											
L	2014	Captiva (3GN)	Body	Theft Deterrent Module				V	V																																																					
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Captiva (Other)	Body	Instrument Cluster																																																										
L	2014	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2014	Captiva (Other)	Body	HVAC Control Module																																																										
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)				V	V	V	V																																																			
L	2014	Captiva (Other)	Body	Theft Deterrent Module				V	V																																																					
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2014	Equinox	Chassis	Power Steering Control Module																																																										
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Equinox	Body	Passenger Presence Module																																																										
L	2014	Equinox	Body	Instrument Cluster																																																										
L	2014	Equinox	Body	Radio																																																										
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2014	Equinox	Body	Liftgate Control Module																																																										
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Parking Assist Control Module																																																										
L	2014	Equinox	Body	Frontview Camera Module																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (3GN)	Body	Body Control Module																																																										
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																																										
L	2015	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2015	Captiva (3GN)	Body	Radio																																																										
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
L	2015	Captiva (3GN)	Body	HVAC Control Module																																																										
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2015	Captiva (3GN)	Body	Theft Deterrent Module				V	V																																																					
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (Other)	Body	Instrument Cluster																																																										
L	2015	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2015	Captiva (Other)	Body	HVAC Control Module																																																										
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)				V	V	V	V																																																		
L	2015	Captiva (Other)	Body	Theft Deterrent Module				V	V																																																				
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																									
L	2015	Equinox	Chassis	Electronic Brake Control Module																																																									
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2015	Equinox	Chassis	Power Steering Control Module																																																									
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																																									
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																									
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2015	Equinox	Body	Passenger Presence Module																																																									
L	2015	Equinox	Body	Instrument Cluster																																																									
L	2015	Equinox	Body	Radio																																																									
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																																									
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																																									
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																																									
L	2015	Equinox	Body	Liftgate Control Module																																																									
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																									
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																									
L	2015	Equinox	Body	Parking Assist Control Module																																																									
L	2015	Equinox	Body	Frontview Camera Module																																																									
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																									
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																									
L	2016	Captiva (3GN)	Body	Body Control Module																																																									
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2016	Captiva (3GN)	Body	Instrument Cluster																																																									
L	2016	Captiva (3GN)	Body	Radio																																																									
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																									
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																									
L	2016	Captiva (3GN)	Body	HVAC Control Module																																																									
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																									
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																									
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																									
L	2016	Captiva (3GN)	Body	Theft Deterrent Module				V	V																																																				
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																									
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																									
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																									
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																									
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																									
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																									
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																									
L	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																									
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																									
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																									
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																									
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2016	Captiva (Other)	Body	Instrument Cluster																																																									
L	2016	Captiva (Other)	Body	Headlamp Control Module																																																									
L	2016	Captiva (Other)	Body	Radio																																																									
L	2016	Captiva (Other)	Body	HVAC Control Module																																																									
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																									
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																									
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																									
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)				V	V	V	V																																																		
L	2016	Captiva (Other)	Body	Theft Deterrent Module				V	V																																																				
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																																									
L	2016	Equinox	Chassis	Electronic Brake Control Module																																																									
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2016	Equinox	Chassis	Power Steering Control Module																																																									
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate																																																									
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																									
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2016	Equinox	Body	Passenger Presence Module																																																									
L	2016	Equinox	Body	Instrument Cluster																																																									
L	2016	Equinox	Body	Radio																																																									
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																																									
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																									
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																																																									
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																																																									
L	2016	Equinox	Body	Liftgate Control Module																																					V	V	V	V	V	V														
L	2016	Equinox	Body	Seat Memory Control Module																																																									
L	2016	Equinox	Body	Right Side Object Detection Control Module																																																									
L	2016	Equinox	Body	Left Side Object Detection Control Module																																																									
L	2016	Equinox	Body	Parking Assist Control Module																																																									
L	2016	Equinox	Body	Frontview Camera Module																																																									
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																													

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
M	2004	ALL	Chassis	4WAL 3 Sensor																																																										
M	2004	ALL	Body	Body Control Module												V	V																																												
M	2004	ALL	Body	Instrument Panel Cluster																																																										
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
M	2005	ALL	Chassis	4WAL 3 Sensor																																																										
M	2005	ALL	Body	Body Control Module												V	V																																												
M	2005	ALL	Body	Instrument Panel Cluster																																																										
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module										V																																															
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module										V																																															
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module										V																																															
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
P	2007	ALL	Body	Theft Deterrent Module																																																										
R	2009	ALL	Powertrain	Engine Control Module																																																										
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2009	ALL	Powertrain	Transmission Control Module																																																										
R	2009	ALL	Chassis	Electronic Brake Control Module																																																										
R	2009	ALL	Body	Body Control Module																																																										
R	2009	ALL	Body	Digital Radio Receiver																																																										
R	2009	ALL	Body	Driver Door Switch																																																										
R	2009	ALL	Body	Heated Seat Module																																																										
R	2009	ALL	Body	HVAC Control Module Auto																																																										
R	2009	ALL	Body	HVAC Control Module Manual																																																										
R	2009	ALL	Body	Instrument Panel Cluster																																																										
R	2009	ALL	Body	Lift Gate Module																																																										
R	2009	ALL	Body	Park Assist Module																																																										
R	2009	ALL	Body	Passenger Door Switch																																																										
R	2009	ALL	Body	Passenger Presence System																																																										
R	2009	ALL	Body	Radio																																																										
R	2009	ALL	Body	Rear HVAC/RSA																																																										
R	2009	ALL	Body	Rollover Sensor																																																										
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2009	ALL	Body	Theft Deterrent Module																									V	V	V	V																														
R	2010	ALL	Powertrain	Engine Control Module																																																										
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2010	ALL	Powertrain	Transmission Control Module																																																										
R	2010	ALL	Chassis	Electronic Brake Control Module																																																										
R	2010	ALL	Body	Body Control Module																																																										
R	2010	ALL	Body	Digital Radio Receiver																																																										
R	2010	ALL	Body	Driver Door Switch																																																										
R	2010	ALL	Body	Heated Seat Module																																																										
R	2010	ALL	Body	HVAC Control Module Auto																																																										
R	2010	ALL	Body	HVAC Control Module Manual																																																										
R	2010	ALL	Body	Instrument Panel Cluster																																																										
R	2010	ALL	Body	Lift Gate Module																																																										
R	2010	ALL	Body	Park Assist Module																																																										
R	2010	ALL	Body	Passenger Door Switch																																																										
R	2010	ALL	Body	Passenger Presence System																																																										
R	2010	ALL	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2010	ALL	Body	Rear HVAC/RSA																																																										
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2010	ALL	Body	Theft Deterrent Module																									V	V	V	V																														
R	2011	ALL	Powertrain	Engine Control Module																																																										
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2011	ALL	Powertrain	Transmission Control Module																																																										
R	2011	ALL	Chassis	Electronic Brake Control Module																																																										
R	2011	ALL	Body	Body Control Module																																																										
R	2011	ALL	Body	Digital Radio Receiver																																																										
R	2011	ALL	Body	Driver Door Switch																																																										
R	2011	ALL	Body	Heated Seat Module																																																										
R	2011	ALL	Body	HVAC Control Module Auto																																																										
R	2011	ALL	Body	HVAC Control Module Manual																																																										
R	2011	ALL	Body	Instrument Panel Cluster																																																										
R	2011	ALL	Body	Lift Gate Module																																																										
R	2011	ALL	Body	Park Assist Module																																																										
R	2011	ALL	Body	Passenger Door Switch																																																										
R	2011	ALL	Body	Passenger Presence System																																																										
R	2011	ALL	Body	Radio																																																										
R	2011	ALL	Body	Rear HVAC/RSA																																																										
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2011	ALL	Body	Theft Deterrent Module																									V	V	V	V																														
R	2012	ALL	Powertrain	Engine Control Module																																																										
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2012	ALL	Powertrain	Transmission Control Module																																																										
R	2012	ALL	Chassis	Electronic Brake Control Module																																																										
R	2012	ALL	Body	Body Control Module																																																										
R	2012	ALL	Body	Digital Radio Receiver																																																										
R	2012	ALL	Body	Driver Door Switch																																																										
R	2012	ALL	Body	Heated Seat Module																																																										
R	2012	ALL	Body	HVAC Control Module Auto																																																										
R	2012	ALL	Body	HVAC Control Module Manual																																																										
R	2012	ALL	Body	Instrument Panel Cluster																																																										
R	2012	ALL	Body	Lift Gate Module																																																										
R	2012	ALL	Body	Park Assist Module																																																										
R	2012	ALL	Body	Passenger Door Switch																																																										
R	2012	ALL	Body	Passenger Presence System																																																										
R	2012	ALL	Body	Radio																																																										
R	2012	ALL	Body	Rear HVAC/RSA																																																										
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2012	ALL	Body	Theft Deterrent Module																									V	V	V	V																														
R	2013	ALL	Powertrain	Engine Control Module																																																										
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2013	ALL	Powertrain	Transmission Control Module																																																										
R	2013	ALL	Chassis	Electronic Brake Control Module																																																										
R	2013	ALL	Body	Body Control Module																																																										
R	2013	ALL	Body	Digital Radio Receiver																																																										
R	2013	ALL	Body	Driver Door Switch																																																										
R	2013	ALL	Body	Heated Seat Module																																																										
R	2013	ALL	Body	HVAC Control Module Auto																																																										
R	2013	ALL	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2013	ALL	Body	Instrument Panel Cluster																																																										
R	2013	ALL	Body	Left Side Object Detection Module																																																											
R	2013	ALL	Body	Lift Gate Module																																																											
R	2013	ALL	Body	Park Assist Module																																																											
R	2013	ALL	Body	Passenger Door Switch																																																											
R	2013	ALL	Body	Passenger Presence System																																																											
R	2013	ALL	Body	Radio																																																											
R	2013	ALL	Body	Rear HVAC/RSA																																																											
R	2013	ALL	Body	Right Side Object Detection Module																																																											
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2013	ALL	Body	Theft Deterrent Module																										V	V	V	V																															
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
R	2014	Traverse	Powertrain	Chassis Control Module																																																											
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																											
R	2014	Traverse	Chassis	Electronic Brake Control Module																																																											
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																											
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																											
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2014	Traverse	Body	Passenger Presence Module																																																											
R	2014	Traverse	Body	Instrument Cluster																																																											
R	2014	Traverse	Body	Radio																																																											
R	2014	Traverse	Body	Rear Audio Control Module																																																											
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																											
R	2014	Traverse	Body	Personal Audio Link Control Module																																																											
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																											
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																											
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																											
R	2014	Traverse	Body	Liftgate Control Module																																																											
R	2014	Traverse	Body	Seat Memory Control Module	V	V	V																																																								
R	2014	Traverse	Body	Front Seat Heating Control Module																																																											
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																											
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																											
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																											
R	2014	Traverse	Body	Parking Assist Control Module																																																											
R	2014	Traverse	Body	Frontview Camera Module																																																											
R	2014	Traverse	Body	Theft Deterrent Module				V	V																																																						
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																											
R	2015	Traverse	Chassis	Electronic Brake Control Module																																																											
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																											
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																											
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2015	Traverse	Body	Passenger Presence Module																																																											
R	2015	Traverse	Body	Instrument Cluster																																																											
R	2015	Traverse	Body	Radio																																																											
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2015	Traverse	Body	Liftgate Control Module																																										V																
R	2015	Traverse	Body	Seat Memory Control Module	V	V	V																																																							
R	2015	Traverse	Body	Front Seat Heating Control Module																																																										
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2015	Traverse	Body	Parking Assist Control Module																																																										
R	2015	Traverse	Body	Frontview Camera Module																																																										
R	2015	Traverse	Body	Theft Deterrent Module				V	V																																																					
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2016	Traverse	Chassis	Electronic Brake Control Module																																																										
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Traverse	Body	Passenger Presence Module																																																										
R	2016	Traverse	Body	Instrument Cluster																																																										
R	2016	Traverse	Body	Radio																																																										
R	2016	Traverse	Body	Rear Audio Control Module																																																										
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																										
R	2016	Traverse	Body	Personal Audio Link Control Module																																																										
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																										
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Traverse	Body	Liftgate Control Module																																										V																
R	2016	Traverse	Body	Seat Memory Control Module	V	V	V																																																							
R	2016	Traverse	Body	Front Seat Heating Control Module																																																										
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2016	Traverse	Body	Parking Assist Control Module																																																										
R	2016	Traverse	Body	Frontview Camera Module																																																										
R	2016	Traverse	Body	Theft Deterrent Module				V	V																																																					
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
S	2004	S10	Chassis	4WAL 3 Sensor																																																										
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																										
S	2004	S10	Body	Body Control Module												V	V																																												
S	2004	S10	Body	Instrument Panel Cluster																																																										
S	2004	S10	Body	Base Radio																																																										
S	2004	S10	Body	Uplevel Radio																																																										
S	2004	S10	Body	Supplemental Inflatable Restraint																																																										
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module											V																																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module											V																																															
S	2004	Colorado	Chassis	ABS Without Traction Control																																																											
S	2004	Colorado	Chassis	ABS With Traction Control																																																											
S	2004	Colorado	Body	Body Control Module																																																											
S	2004	Colorado	Body	Instrument Panel Cluster																																																											
S	2004	Colorado	Body	OnStar																																																											
S	2004	Colorado	Body	Base Radio																																																											
S	2004	Colorado	Body	Uplevel Radio																																																											
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																																											
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																																
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																											
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																											
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																											
S	2004	TrailBlazer	Body	Body Control Module																																																											
S	2004	TrailBlazer	Body	Driver Door Module																																																											
S	2004	TrailBlazer	Body	Driver Seat Module																																																											
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																											
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																											
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																																											
S	2004	TrailBlazer	Body	Lift Gate Module																																																											
S	2004	TrailBlazer	Body	OnStar																																																											
S	2004	TrailBlazer	Body	Passenger Door Module																																																											
S	2004	TrailBlazer	Body	Uplevel Radio																																																											
S	2004	TrailBlazer	Body	Navigation Radio																																																											
S	2004	TrailBlazer	Body	Rear Seat Audio																																																											
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																											
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																											
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																																
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																											
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module											V																																																
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																											
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																											
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																											
S	2004	TrailBlazer EXT	Body	Body Control Module																																																											
S	2004	TrailBlazer EXT	Body	Driver Door Module																																																											
S	2004	TrailBlazer EXT	Body	Driver Seat Module																																																											
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																											
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																											
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																											
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																											
S	2004	TrailBlazer EXT	Body	OnStar																																																											
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																																											
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																											
S	2004	TrailBlazer EXT	Body	Navigation Radio																																																											
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																										
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																										
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Blazer	Body	Body Control Module												V	V																																												
S	2004	Blazer	Body	Heating and Air Conditioning																																																										
S	2004	Blazer	Body	Instrument Panel Cluster																																																										
S	2004	Blazer	Body	Memory Seat Module																																																										
S	2004	Blazer	Body	Base Radio																																																										
S	2004	Blazer	Body	Uplevel Radio																																																										
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																																										
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module											V																																														
S	2004	SSR	Chassis	4WAL 3 Sensor																																																										
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																										
S	2004	SSR	Body	Amplifier (Bose)																																																										
S	2004	SSR	Body	Body Control Module																																																										
S	2004	SSR	Body	Driver Seat Module																																																										
S	2004	SSR	Body	Instrument Panel Cluster																																																										
S	2004	SSR	Body	Uplevel Radio																																																										
S	2004	SSR	Body	Remote Function Actuation																																																										
S	2004	SSR	Body	Roof and Door Module																																																										
S	2004	SSR	Body	Supplemental Inflatable Restraint																																																										
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module											V																																														
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module											V																																														
S	2005	Colorado	Chassis	ABS Without Traction Control																																																										
S	2005	Colorado	Chassis	ABS With Traction Control																																																										
S	2005	Colorado	Body	Body Control Module																																																										
S	2005	Colorado	Body	Instrument Panel Cluster																																																										
S	2005	Colorado	Body	Base Radio																																																										
S	2005	Colorado	Body	Uplevel Radio																																																										
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																																										
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																										
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
S	2005	TrailBlazer	Body	Body Control Module																																																										
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2005	TrailBlazer	Body	Driver Door Module																																																										
S	2005	TrailBlazer	Body	Driver Seat Module																																																										
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2005	TrailBlazer	Body	Lift Gate Module																																																									
S	2005	TrailBlazer	Body	Passenger Door Module																																																										
S	2005	TrailBlazer	Body	Passenger Presence System																																																										
S	2005	TrailBlazer	Body	Uplevel Radio																																																										
S	2005	TrailBlazer	Body	Navigation Radio																																																										
S	2005	TrailBlazer	Body	Rear Seat Audio																																																										
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
S	2005	TrailBlazer EXT	Body	Body Control Module																																																										
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
S	2005	TrailBlazer EXT	Body	Driver Door Module																																																										
S	2005	TrailBlazer EXT	Body	Driver Seat Module																																																										
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																										
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																																										
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																										
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																										
S	2005	TrailBlazer EXT	Body	Navigation Radio																																																										
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																										
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																										
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																										
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Blazer	Body	Body Control Module												V	V																																												
S	2005	Blazer	Body	Heating and Air Conditioning																																																										
S	2005	Blazer	Body	Instrument Panel Cluster																																																										
S	2005	Blazer	Body	Memory Seat Module																																																										
S	2005	Blazer	Body	Base Radio																																																										
S	2005	Blazer	Body	Uplevel Radio																																																										
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																																										
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2005	SSR	Chassis	4WAL 3 Sensor																																																										
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																										
S	2005	SSR	Body	Amplifier (Bose)																																																										
S	2005	SSR	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2005	SSR	Body	Driver Seat Module																																																										
S	2005	SSR	Body	Instrument Panel Cluster																																																										
S	2005	SSR	Body	Uplevel Radio																																																										
S	2005	SSR	Body	Remote Function Actuation																																																										
S	2005	SSR	Body	Roof and Door Module																																																										
S	2005	SSR	Body	Supplemental Inflatable Restraint																																																										
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module											V																																														
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module											V																																														
S	2006	Colorado	Chassis	ABS Without Traction Control																																																										
S	2006	Colorado	Chassis	ABS With Traction Control																																																										
S	2006	Colorado	Body	Body Control Module																																																										
S	2006	Colorado	Body	Instrument Panel Cluster																																																										
S	2006	Colorado	Body	Passenger Presence System																																																										
S	2006	Colorado	Body	Base Radio																																																										
S	2006	Colorado	Body	Uplevel Radio																																																										
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																																										
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																										
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																										
S	2006	TrailBlazer	Body	Body Control Module																																																										
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2006	TrailBlazer	Body	Driver Door Module																																																										
S	2006	TrailBlazer	Body	Driver Seat Module																																																										
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																																										
S	2006	TrailBlazer	Body	Lift Gate Module																																																										
S	2006	TrailBlazer	Body	Passenger Door Module																																																										
S	2006	TrailBlazer	Body	Passenger Presence System																																																										
S	2006	TrailBlazer	Body	Uplevel Radio																																																										
S	2006	TrailBlazer	Body	Navigation Radio																																																										
S	2006	TrailBlazer	Body	Rear Seat Audio																																																										
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																										
S	2006	TrailBlazer EXT	Body	Body Control Module																																																										
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
S	2006	TrailBlazer EXT	Body	Driver Door Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2006	TrailBlazer EXT	Body	Driver Seat Module																																																										
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																										
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																																										
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																										
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																										
S	2006	TrailBlazer EXT	Body	Navigation Radio																																																										
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																										
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																										
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2006	SSR	Chassis	4WAL 3 Sensor																																																										
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																										
S	2006	SSR	Body	Amplifier (Bose)																																																										
S	2006	SSR	Body	Body Control Module																																																										
S	2006	SSR	Body	Driver Seat Module																																																										
S	2006	SSR	Body	Instrument Panel Cluster																																																										
S	2006	SSR	Body	Uplevel Radio																																																										
S	2006	SSR	Body	Remote Function Actuation																																																										
S	2006	SSR	Body	Roof and Door Module																																																										
S	2006	SSR	Body	Supplemental Inflatable Restraint																																																										
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module											V																																															
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module											V																																															
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																										
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																										
S	2007	Colorado	Body	Body Control Module																																																										
S	2007	Colorado	Body	Digital Radio Receiver																																																										
S	2007	Colorado	Body	Generator Battery Control Module																																																										
S	2007	Colorado	Body	Instrument Panel Cluster																																																										
S	2007	Colorado	Body	Passenger Presence System																																																										
S	2007	Colorado	Body	Base Radio																																																										
S	2007	Colorado	Body	Uplevel Radio																																																										
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																																										
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																															
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																						V																																				
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module											V																																															
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2007	Trailblazer	Body	Body Control Module																																																										
S	2007	Trailblazer	Body	Digital Radio Receiver																																																										
S	2007	Trailblazer	Body	Disc Player and Video Display																																																										
S	2007	Trailblazer	Body	Driver Door Module																																																										
S	2007	Trailblazer	Body	Driver Seat Module																																																										
S	2007	Trailblazer	Body	Generator Battery Control Module																																																										
S	2007	Trailblazer	Body	HVAC Control Module Auto																																																										
S	2007	Trailblazer	Body	HVAC Control Module Manual																																																										
S	2007	Trailblazer	Body	Instrument Panel Cluster																																																										
S	2007	Trailblazer	Body	Lift Gate Module																																																										
S	2007	Trailblazer	Body	Passenger Door Module																																																										
S	2007	Trailblazer	Body	Passenger Presence System																																																										
S	2007	Trailblazer	Body	Uplevel Radio																																																										
S	2007	Trailblazer	Body	Navigation Radio																																																										
S	2007	Trailblazer	Body	Rear Seat Audio																																																										
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																										
S	2007	Trailblazer	Body	Theft Deterrent Module																																																										
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																										
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																										
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																										
S	2008	Colorado	Body	Body Control Module																																																										
S	2008	Colorado	Body	Digital Radio Receiver																																																										
S	2008	Colorado	Body	Generator Battery Control Module																																																										
S	2008	Colorado	Body	Instrument Panel Cluster																																																										
S	2008	Colorado	Body	Passenger Presence System																																																										
S	2008	Colorado	Body	Base Radio																																																										
S	2008	Colorado	Body	Uplevel Radio																																																										
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2008	Colorado	Body	Theft Deterrent Module																																																										
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																																										
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																										
S	2008	TrailBlazer	Body	Body Control Module																																																										
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																										
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2008	TrailBlazer	Body	Driver Door Module																																																										
S	2008	TrailBlazer	Body	Driver Seat Module																																																										
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																										
S	2008	TrailBlazer	Body	HVAC Control Module Auto																																																										
S	2008	TrailBlazer	Body	HVAC Control Module Manual																																																										
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																																										
S	2008	TrailBlazer	Body	Lift Gate Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2008	TrailBlazer	Body	Passenger Door Module																																																										
S	2008	TrailBlazer	Body	Passenger Presence System																																																										
S	2008	TrailBlazer	Body	Uplevel Radio																																																										
S	2008	TrailBlazer	Body	Navigation Radio																																																										
S	2008	TrailBlazer	Body	Rear Seat Audio																																																										
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2008	TrailBlazer	Body	Theft Deterrent Module																																																										
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																										
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
S	2009	Colorado	Chassis	Electronic Brake Control Module																																																										
S	2009	Colorado	Body	Body Control Module																																																										
S	2009	Colorado	Body	Digital Radio Receiver																																																										
S	2009	Colorado	Body	Generator Battery Control Module																																																										
S	2009	Colorado	Body	Instrument Panel Cluster																																																										
S	2009	Colorado	Body	Passenger Presence System																																																										
S	2009	Colorado	Body	Base Radio																																																										
S	2009	Colorado	Body	Uplevel Radio																																																										
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2009	Colorado	Body	Theft Deterrent Module																																																										
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																										
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																										
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																										
S	2009	TrailBlazer	Body	Body Control Module																																																										
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																										
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2009	TrailBlazer	Body	Driver Door Module																																																										
S	2009	TrailBlazer	Body	Driver Seat Module																																																										
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																										
S	2009	TrailBlazer	Body	HVAC Control Module Auto																																																										
S	2009	TrailBlazer	Body	HVAC Control Module Manual																																																										
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																																										
S	2009	TrailBlazer	Body	Lift Gate Module																																																										
S	2009	TrailBlazer	Body	Passenger Door Module																																																										
S	2009	TrailBlazer	Body	Passenger Presence System																																																										
S	2009	TrailBlazer	Body	Uplevel Radio																																																										
S	2009	TrailBlazer	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2009	TrailBlazer	Body	Rear Seat Audio																																																										
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2009	TrailBlazer	Body	Theft Deterrent Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																					
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																					
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
S	2010	ALL	Chassis	Electronic Brake Control Module																																																											
S	2010	ALL	Body	Body Control Module																																																										
S	2010	ALL	Body	Digital Radio Receiver																																																										
S	2010	ALL	Body	Generator Battery Control Module																																																										
S	2010	ALL	Body	Instrument Panel Cluster																																																										
S	2010	ALL	Body	Passenger Presence System																																																										
S	2010	ALL	Body	Personal Audio Link Module																																																										
S	2010	ALL	Body	Base Radio																																																										
S	2010	ALL	Body	Uplevel Radio																																																										
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
S	2010	ALL	Body	Theft Deterrent Module																																																										
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																										
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																					
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																					
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
S	2011	ALL	Chassis	Electronic Brake Control Module																																																											
S	2011	ALL	Body	Body Control Module																																																										
S	2011	ALL	Body	Digital Radio Receiver																																																										
S	2011	ALL	Body	Generator Battery Control Module																																																										
S	2011	ALL	Body	Instrument Panel Cluster																																																										
S	2011	ALL	Body	Passenger Presence System																																																										
S	2011	ALL	Body	Personal Audio Link Module																																																										
S	2011	ALL	Body	Base Radio																																																										
S	2011	ALL	Body	Uplevel Radio																																																										
S	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
S	2011	ALL	Body	Theft Deterrent Module																																																										
S	2011	ALL	Body	Vehicle Comm. Interface Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																					
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																					
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																										
S	2012	Colorado (First Gen)	Body	Body Control Module																																																										
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																										
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																										
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																										
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																										
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																										
S	2012	Colorado (First Gen)	Body	Base Radio																																																										
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																										
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																										
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																										
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																	V																										
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																										
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2012	Colorado (Second Gen)	Body	Body Control Module																																																										
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																										
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																										
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2012	S10	Powertrain	Transfer Case Control Module																																	V																										
S	2012	S10	Chassis	Electronic Brake Control Module																																																										
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2012	S10	Body	Body Control Module																																																										
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	S10	Body	Instrument Cluster																																																										
S	2012	S10	Body	Trailer Interface Control Module																																																										
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																									
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																									
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																									
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																									
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																									
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																									
S	2013	Colorado	Powertrain	Transfer Case Control Module																																	V																										
S	2013	Colorado	Chassis	Electronic Brake Control Module																																																									
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2013	Colorado	Body	Body Control Module																																																									
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2013	Colorado	Body	Instrument Cluster																																																									
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																									
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																									
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																									
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																									
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																									
S	2013	S10	Powertrain	Transfer Case Control Module																																	V																										
S	2013	S10	Chassis	Electronic Brake Control Module																																																									
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2013	S10	Body	Body Control Module																																																									
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2013	S10	Body	Instrument Cluster																																																									
S	2013	S10	Body	Trailer Interface Control Module																																																									
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																									
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																									
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																									
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																									
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																									
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																									
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																	V																										
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																									
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2013	Trailblazer	Body	Body Control Module																																																									
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2013	Trailblazer	Body	Instrument Cluster																																																									
S	2013	Trailblazer	Body	Trailer Interface Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2013	Trailblazer	Body	Parking Assist Control Module																																																								
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																									
S	2014	Colorado	Powertrain	Transfer Case Control Module																																	V																										
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																									
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2014	Colorado	Body	Body Control Module																																																								
S	2014	Colorado	Body	Body Control Module																																																								
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2014	Colorado	Body	Instrument Cluster																																																								
S	2014	Colorado	Body	Radio																																																								
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																								
S	2014	Colorado	Body	Parking Assist Control Module																																																								
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2014	S10	Powertrain	Transfer Case Control Module																																	V																								
S	2014	S10	Chassis	Electronic Brake Control Module																																																								
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2014	S10	Body	Body Control Module																																																								
S	2014	S10	Body	Body Control Module																																																								
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2014	S10	Body	Instrument Cluster																																																								
S	2014	S10	Body	Trailer Interface Control Module																																																								
S	2014	S10	Body	Radio																																																								
S	2014	S10	Body	Parking Assist Control Module																																																								
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																								
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																								
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																	V																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																										
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2014	Trailblazer	Body	Body Control Module																																																										
S	2014	Trailblazer	Body	Body Control Module																																																										
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Trailblazer	Body	Instrument Cluster																																																										
S	2014	Trailblazer	Body	Trailer Interface Control Module																																																										
S	2014	Trailblazer	Body	Parking Assist Control Module																																																										
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2015	Colorado	Powertrain	Chassis Control Module																																																										
S	2015	Colorado	Powertrain	Transfer Case Control Module																																V	V																										
S	2015	Colorado	Chassis	Electronic Brake Control Module																																																										
S	2015	Colorado	Chassis	Power Steering Control Module																																																										
S	2015	Colorado	Body	Body Control Module																																																										
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Colorado	Body	Passenger Presence Module																																																										
S	2015	Colorado	Body	Radio																																																										
S	2015	Colorado	Body	Amplifier																																																										
S	2015	Colorado	Body	Human Machine Interface Control Module																																																										
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																																										
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																										
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																										
S	2015	Colorado	Body	Frontview Camera Module																																																										
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																	V																										
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																										
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	Colorado (MMM)	Body	Body Control Module																																																										
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2015	Colorado (MMM)	Body	Instrument Cluster																																																										
S	2015	Colorado (MMM)	Body	Radio																																																										
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																										
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	S10	Powertrain	Transfer Case Control Module																																	V																											
S	2015	S10	Chassis	Electronic Brake Control Module																																																										
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	S10	Body	Body Control Module																																																										
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	S10	Body	Instrument Cluster																																																										
S	2015	S10	Body	Trailer Interface Control Module																																																										
S	2015	S10	Body	Radio																																																										
S	2015	S10	Body	Telematics Communication Interface Control Module																																																										
S	2015	S10	Body	Parking Assist Control Module																																																										
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																	V																											
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																										
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	Trailblazer	Body	Body Control Module																																																										
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Trailblazer	Body	Instrument Cluster																																																										
S	2015	Trailblazer	Body	Trailer Interface Control Module																																																										
S	2015	Trailblazer	Body	Radio																																																									
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																										
S	2015	Trailblazer	Body	Parking Assist Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																V	V																								
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																								
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																								
S	2016	Colorado (1GC)	Body	Body Control Module																																																								
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																																								
S	2016	Colorado (1GC)	Body	Radio Controls																																																								
S	2016	Colorado (1GC)	Body	HVAC Controls																																																								
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																								
S	2016	Colorado (1GC)	Body	Radio																																																								
S	2016	Colorado (1GC)	Body	Amplifier																																																								
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																								
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																								
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																								
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																								
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																								
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																																								
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																	V																								
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																								
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2016	Colorado (MMM)	Body	Body Control Module																																																								
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2016	Colorado (MMM)	Body	Instrument Cluster																																																								
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																								
S	2016	Colorado (MMM)	Body	Radio																																																								
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																								
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																								
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																								
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																								
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																								
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
S	2016	S10	Powertrain	Transfer Case Control Module																																	V																								
S	2016	S10	Chassis	Electronic Brake Control Module																																																								
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2016	S10	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2016	S10	Body	Instrument Cluster																																																									
S	2016	S10	Body	Trailer Interface Control Module																																																									
S	2016	S10	Body	Radio																																																									
S	2016	S10	Body	Telematics Communication Interface Control Module																																																									
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																									
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																									
S	2016	S10	Body	Parking Assist Control Module																																																									
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																									
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																	V																										
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																									
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2016	Trailblazer	Body	Body Control Module																																																									
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2016	Trailblazer	Body	Instrument Cluster																																																									
S	2016	Trailblazer	Body	Trailer Interface Control Module																																																									
S	2016	Trailblazer	Body	Radio																																																									
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																									
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																									
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																									
S	2016	Trailblazer	Body	Parking Assist Control Module																																																									
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																													
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2004	S10	Chassis	4WAL 3 Sensor																																																									
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																									
T	2004	S10	Body	Body Control Module												V	V																																											
T	2004	S10	Body	Instrument Panel Cluster																																																									
T	2004	S10	Body	Base Radio																																																									
T	2004	S10	Body	Uplevel Radio																																																									
T	2004	S10	Body	Supplemental Inflatable Restraint																																																									
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module											V																																														
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module											V																																														
T	2004	Colorado	Chassis	ABS Without Traction Control																																																									
T	2004	Colorado	Chassis	ABS With Traction Control																																																									
T	2004	Colorado	Body	Body Control Module																																																									
T	2004	Colorado	Body	Instrument Panel Cluster																																																									
T	2004	Colorado	Body	OnStar																																																									
T	2004	Colorado	Body	Base Radio																																																									
T	2004	Colorado	Body	Uplevel Radio																																																									
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																																									
T	2004	Colorado	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																															
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer	Body	Body Control Module																																																										
T	2004	TrailBlazer	Body	Driver Door Module																																																										
T	2004	TrailBlazer	Body	Driver Seat Module																																																										
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2004	TrailBlazer	Body	Lift Gate Module																																																										
T	2004	TrailBlazer	Body	OnStar																																																										
T	2004	TrailBlazer	Body	Passenger Door Module																																																										
T	2004	TrailBlazer	Body	Uplevel Radio																																																										
T	2004	TrailBlazer	Body	Navigation Radio																																																										
T	2004	TrailBlazer	Body	Rear Seat Audio																																																										
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																															
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module											V																																															
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer EXT	Body	Body Control Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Seat Module																																																										
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2004	TrailBlazer EXT	Body	OnStar																																																										
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2004	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																										
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Blazer	Body	Body Control Module												V	V																																												
T	2004	Blazer	Body	Heating and Air Conditioning																																																										
T	2004	Blazer	Body	Instrument Panel Cluster																																																										
T	2004	Blazer	Body	Memory Seat Module																																																										
T	2004	Blazer	Body	Base Radio																																																										
T	2004	Blazer	Body	Uplevel Radio																																																										
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																																										
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module											V																																															
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module											V																																															
T	2005	Colorado	Chassis	ABS Without Traction Control																																																										
T	2005	Colorado	Chassis	ABS With Traction Control																																																										
T	2005	Colorado	Body	Body Control Module																																																										
T	2005	Colorado	Body	Instrument Panel Cluster																																																										
T	2005	Colorado	Body	Base Radio																																																										
T	2005	Colorado	Body	Uplevel Radio																																																										
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																															
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																										
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
T	2005	TrailBlazer	Body	Body Control Module																																																										
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2005	TrailBlazer	Body	Driver Door Module																																																										
T	2005	TrailBlazer	Body	Driver Seat Module																																																										
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2005	TrailBlazer	Body	Lift Gate Module																																																										
T	2005	TrailBlazer	Body	Passenger Door Module																																																										
T	2005	TrailBlazer	Body	Passenger Presence System																																																										
T	2005	TrailBlazer	Body	Uplevel Radio																																																										
T	2005	TrailBlazer	Body	Navigation Radio																																																										
T	2005	TrailBlazer	Body	Rear Seat Audio																																																										
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																															
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
T	2005	TrailBlazer EXT	Body	Body Control Module																																																										
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
T	2005	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2005	TrailBlazer EXT	Body	Driver Seat Module																																																										
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																										
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2005	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																										
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																										
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																										
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Blazer	Body	Body Control Module												V	V																																												
T	2005	Blazer	Body	Heating and Air Conditioning																																																										
T	2005	Blazer	Body	Instrument Panel Cluster																																																										
T	2005	Blazer	Body	Memory Seat Module																																																										
T	2005	Blazer	Body	Base Radio																																																										
T	2005	Blazer	Body	Uplevel Radio																																																										
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																																										
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module											V																																														
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module											V																																														
T	2006	Colorado	Chassis	ABS Without Traction Control																																																										
T	2006	Colorado	Chassis	ABS With Traction Control																																																										
T	2006	Colorado	Body	Body Control Module																																																										
T	2006	Colorado	Body	Instrument Panel Cluster																																																										
T	2006	Colorado	Body	Passenger Presence System																																																										
T	2006	Colorado	Body	Base Radio																																																										
T	2006	Colorado	Body	Uplevel Radio																																																										
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																																										
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																										
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																										
T	2006	TrailBlazer	Body	Body Control Module																																																										
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2006	TrailBlazer	Body	Driver Door Module																																																										
T	2006	TrailBlazer	Body	Driver Seat Module																																																										
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2006	TrailBlazer	Body	Lift Gate Module																																																										
T	2006	TrailBlazer	Body	Passenger Door Module																																																										
T	2006	TrailBlazer	Body	Passenger Presence System																																																										
T	2006	TrailBlazer	Body	Uplevel Radio																																																										
T	2006	TrailBlazer	Body	Navigation Radio																																																										
T	2006	TrailBlazer	Body	Rear Seat Audio																																																										
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																										
T	2006	TrailBlazer EXT	Body	Body Control Module																																																										
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
T	2006	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2006	TrailBlazer EXT	Body	Driver Seat Module																																																										
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																										
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2006	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																										
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																										
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module											V																																														
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module											V																																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																										
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																										
T	2007	Colorado	Body	Body Control Module																																																										
T	2007	Colorado	Body	Digital Radio Receiver																																																										
T	2007	Colorado	Body	Generator Battery Control Module																																																										
T	2007	Colorado	Body	Instrument Panel Cluster																																																										
T	2007	Colorado	Body	Passenger Presence System																																																										
T	2007	Colorado	Body	Base Radio																																																										
T	2007	Colorado	Body	Uplevel Radio																																																										
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																															
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																						V																																				
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module											V																																															
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																										
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																										
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2007	Trailblazer	Body	Body Control Module																																																										
T	2007	Trailblazer	Body	Digital Radio Receiver																																																										
T	2007	Trailblazer	Body	Disc Player and Video Display																																																										
T	2007	Trailblazer	Body	Driver Door Module																																																										
T	2007	Trailblazer	Body	Driver Seat Module																																																										
T	2007	Trailblazer	Body	Generator Battery Control Module																																																										
T	2007	Trailblazer	Body	HVAC Control Module Auto																																																										
T	2007	Trailblazer	Body	HVAC Control Module Manual																																																										
T	2007	Trailblazer	Body	Instrument Panel Cluster																																																										
T	2007	Trailblazer	Body	Lift Gate Module																																																										
T	2007	Trailblazer	Body	Passenger Door Module																																																										
T	2007	Trailblazer	Body	Passenger Presence System																																																										
T	2007	Trailblazer	Body	Uplevel Radio																																																										
T	2007	Trailblazer	Body	Navigation Radio																																																										
T	2007	Trailblazer	Body	Rear Seat Audio																																																										
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																										
T	2007	Trailblazer	Body	Theft Deterrent Module																																																										
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																										
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2008	Colorado	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2008	Colorado	Body	Digital Radio Receiver																																																										
T	2008	Colorado	Body	Generator Battery Control Module																																																											
T	2008	Colorado	Body	Instrument Panel Cluster																																																											
T	2008	Colorado	Body	Passenger Presence System																																																											
T	2008	Colorado	Body	Base Radio																																																											
T	2008	Colorado	Body	Uplevel Radio																																																											
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																																											
T	2008	Colorado	Body	Theft Deterrent Module																																																											
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																																											
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																						
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
T	2008	TrailBlazer	Body	Body Control Module																																																												
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																												
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																												
T	2008	TrailBlazer	Body	Driver Door Module																																																												
T	2008	TrailBlazer	Body	Driver Seat Module																																																												
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																												
T	2008	TrailBlazer	Body	HVAC Control Module Auto																																																												
T	2008	TrailBlazer	Body	HVAC Control Module Manual																																																												
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																																												
T	2008	TrailBlazer	Body	Lift Gate Module																																																												
T	2008	TrailBlazer	Body	Passenger Door Module																																																												
T	2008	TrailBlazer	Body	Passenger Presence System																																																												
T	2008	TrailBlazer	Body	Uplevel Radio																																																												
T	2008	TrailBlazer	Body	Navigation Radio																																																												
T	2008	TrailBlazer	Body	Rear Seat Audio																																																												
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
T	2008	TrailBlazer	Body	Theft Deterrent Module																																																												
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																												
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																						
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																						
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																												
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																												
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																												
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																												
T	2009	Colorado	Chassis	Electronic Brake Control Module																																																												
T	2009	Colorado	Body	Body Control Module																																																												
T	2009	Colorado	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2009	Colorado	Body	Generator Battery Control Module																																																										
T	2009	Colorado	Body	Instrument Panel Cluster																																																											
T	2009	Colorado	Body	Passenger Presence System																																																											
T	2009	Colorado	Body	Base Radio																																																											
T	2009	Colorado	Body	Uplevel Radio																																																											
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																																											
T	2009	Colorado	Body	Theft Deterrent Module																																																											
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																						
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
T	2009	TrailBlazer	Body	Body Control Module																																																												
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																												
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																												
T	2009	TrailBlazer	Body	Driver Door Module																																																												
T	2009	TrailBlazer	Body	Driver Seat Module																																																												
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																												
T	2009	TrailBlazer	Body	HVAC Control Module Auto																																																												
T	2009	TrailBlazer	Body	HVAC Control Module Manual																																																												
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																																												
T	2009	TrailBlazer	Body	Lift Gate Module																																																												
T	2009	TrailBlazer	Body	Passenger Door Module																																																												
T	2009	TrailBlazer	Body	Passenger Presence System																																																												
T	2009	TrailBlazer	Body	Uplevel Radio																																																												
T	2009	TrailBlazer	Body	Navigation Radio																																																												
T	2009	TrailBlazer	Body	Rear Seat Audio																																																												
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
T	2009	TrailBlazer	Body	Theft Deterrent Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																						
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																						
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																												
T	2010	ALL	Chassis	Electronic Brake Control Module																																																												
T	2010	ALL	Body	Body Control Module																																																											
T	2010	ALL	Body	Digital Radio Receiver																																																												
T	2010	ALL	Body	Generator Battery Control Module																																																												
T	2010	ALL	Body	Instrument Panel Cluster																																																												
T	2010	ALL	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2010	ALL	Body	Personal Audio Link Module																																																										
T	2010	ALL	Body	Base Radio																																																										
T	2010	ALL	Body	Uplevel Radio																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Theft Deterrent Module																																																										
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																										
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
T	2011	ALL	Chassis	Electronic Brake Control Module																																																										
T	2011	ALL	Body	Body Control Module																																																										
T	2011	ALL	Body	Digital Radio Receiver																																																										
T	2011	ALL	Body	Generator Battery Control Module																																																										
T	2011	ALL	Body	Instrument Panel Cluster																																																										
T	2011	ALL	Body	Passenger Presence System																																																										
T	2011	ALL	Body	Personal Audio Link Module																																																										
T	2011	ALL	Body	Base Radio																																																										
T	2011	ALL	Body	Uplevel Radio																																																										
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2011	ALL	Body	Theft Deterrent Module																																																										
T	2011	ALL	Body	Vehicle Comm. Interface Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																										
T	2012	Colorado (First Gen)	Body	Body Control Module																																																										
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																										
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																										
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																										
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																										
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																										
T	2012	Colorado (First Gen)	Body	Base Radio																																																										
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																								
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																								
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																	V																							
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																								
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2012	Colorado (Second Gen)	Body	Body Control Module																																																								
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																								
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																								
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2012	S10	Powertrain	Transfer Case Control Module																																	V																							
T	2012	S10	Chassis	Electronic Brake Control Module																																																								
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2012	S10	Body	Body Control Module																																																								
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	S10	Body	Instrument Cluster																																																								
T	2012	S10	Body	Trailer Interface Control Module																																																								
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2013	Colorado	Powertrain	Transfer Case Control Module																																	V																							
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																								
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2013	Colorado	Body	Body Control Module																																																										
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	Colorado	Body	Instrument Cluster																																																										
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2013	S10	Powertrain	Transfer Case Control Module																																V																											
T	2013	S10	Chassis	Electronic Brake Control Module																																																										
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2013	S10	Body	Body Control Module																																																										
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	S10	Body	Instrument Cluster																																																										
T	2013	S10	Body	Trailer Interface Control Module																																																										
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																V																											
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2013	Trailblazer	Body	Body Control Module																																																										
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2013	Trailblazer	Body	Instrument Cluster																																																										
T	2013	Trailblazer	Body	Trailer Interface Control Module																																																										
T	2013	Trailblazer	Body	Parking Assist Control Module																																																										
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2014	Colorado	Powertrain	Transfer Case Control Module																																V																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																									
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2014	Colorado	Body	Body Control Module																																																									
T	2014	Colorado	Body	Body Control Module																																																									
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2014	Colorado	Body	Instrument Cluster																																																									
T	2014	Colorado	Body	Radio																																																									
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																									
T	2014	Colorado	Body	Parking Assist Control Module																																																									
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2014	S10	Powertrain	Transfer Case Control Module																																	V																										
T	2014	S10	Chassis	Electronic Brake Control Module																																																									
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2014	S10	Body	Body Control Module																																																									
T	2014	S10	Body	Body Control Module																																																									
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2014	S10	Body	Instrument Cluster																																																									
T	2014	S10	Body	Trailer Interface Control Module																																																									
T	2014	S10	Body	Radio																																																									
T	2014	S10	Body	Parking Assist Control Module																																																									
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																									
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																	V																										
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																									
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2014	Trailblazer	Body	Body Control Module																																																									
T	2014	Trailblazer	Body	Body Control Module																																																									
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2014	Trailblazer	Body	Instrument Cluster																																																									
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																									
T	2014	Trailblazer	Body	Parking Assist Control Module																																																									
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																								
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
T	2015	Colorado	Powertrain	Chassis Control Module																																																								
T	2015	Colorado	Powertrain	Transfer Case Control Module																																V	V																								
T	2015	Colorado	Chassis	Electronic Brake Control Module																																																								
T	2015	Colorado	Chassis	Power Steering Control Module																																																								
T	2015	Colorado	Body	Body Control Module																																																								
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2015	Colorado	Body	Passenger Presence Module																																																								
T	2015	Colorado	Body	Radio																																																								
T	2015	Colorado	Body	Amplifier																																																								
T	2015	Colorado	Body	Human Machine Interface Control Module																																																								
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																																								
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																								
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																								
T	2015	Colorado	Body	Frontview Camera Module																																																								
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																								
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																	V																							
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																								
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2015	Colorado (MMM)	Body	Body Control Module																																																								
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2015	Colorado (MMM)	Body	Instrument Cluster																																																								
T	2015	Colorado (MMM)	Body	Radio																																																								
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																								
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																								
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2015	S10	Powertrain	Transfer Case Control Module																																V																										
T	2015	S10	Chassis	Electronic Brake Control Module																																																									
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2015	S10	Body	Body Control Module																																																									
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	S10	Body	Instrument Cluster																																																									
T	2015	S10	Body	Trailer Interface Control Module																																																									
T	2015	S10	Body	Radio																																																									
T	2015	S10	Body	Telematics Communication Interface Control Module																																																									
T	2015	S10	Body	Parking Assist Control Module																																																									
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																V																										
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																									
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2015	Trailblazer	Body	Body Control Module																																																									
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Trailblazer	Body	Instrument Cluster																																																									
T	2015	Trailblazer	Body	Trailer Interface Control Module																																																									
T	2015	Trailblazer	Body	Radio																																																									
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																									
T	2015	Trailblazer	Body	Parking Assist Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																V	V																									
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																									
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																									
T	2016	Colorado (1GC)	Body	Body Control Module																																																									
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																																									
T	2016	Colorado (1GC)	Body	Radio Controls																																																									
T	2016	Colorado (1GC)	Body	HVAC Controls																																																									
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																									
T	2016	Colorado (1GC)	Body	Radio																																																									
T	2016	Colorado (1GC)	Body	Amplifier																																																									
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																								
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																								
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																								
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																								
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																								
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																V																										
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																								
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2016	Colorado (MMM)	Body	Body Control Module																																																								
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																								
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																								
T	2016	Colorado (MMM)	Body	Radio																																																								
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																								
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																								
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																								
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																								
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																								
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
T	2016	S10	Powertrain	Transfer Case Control Module																																V																										
T	2016	S10	Chassis	Electronic Brake Control Module																																																								
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2016	S10	Body	Body Control Module																																																								
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2016	S10	Body	Instrument Cluster																																																								
T	2016	S10	Body	Trailer Interface Control Module																																																								
T	2016	S10	Body	Radio																																																								
T	2016	S10	Body	Telematics Communication Interface Control Module																																																								
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																								
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																								
T	2016	S10	Body	Parking Assist Control Module																																																								
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																V																									
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																									
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2016	Trailblazer	Body	Body Control Module																																																									
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2016	Trailblazer	Body	Instrument Cluster																																																									
T	2016	Trailblazer	Body	Trailer Interface Control Module																																																									
T	2016	Trailblazer	Body	Radio																																																									
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																									
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																									
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																									
T	2016	Trailblazer	Body	Parking Assist Control Module																																																									
V	2009	ALL	Powertrain	Engine Control Module																																																									
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2009	ALL	Powertrain	Rear Drive System																																																									
V	2009	ALL	Powertrain	Transmission Control Module																																																									
V	2009	ALL	Chassis	Electronic Brake Control Module																																																									
V	2009	ALL	Body	Body Control Module																																																									
V	2009	ALL	Body	Digital Radio Receiver																																																									
V	2009	ALL	Body	Driver Door Switch																																																									
V	2009	ALL	Body	Heated Seat Module																																																									
V	2009	ALL	Body	HVAC Control Module Auto																																																									
V	2009	ALL	Body	HVAC Control Module Manual																																																									
V	2009	ALL	Body	Instrument Panel Cluster																																																									
V	2009	ALL	Body	Lift Gate Module																																																									
V	2009	ALL	Body	Park Assist Module																																																									
V	2009	ALL	Body	Passenger Door Switch																																																									
V	2009	ALL	Body	Passenger Presence System																																																									
V	2009	ALL	Body	Radio																																																									
V	2009	ALL	Body	Rear HVAC/RSA																																																									
V	2009	ALL	Body	Rollover Sensor																																																									
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2009	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
V	2010	ALL	Powertrain	Engine Control Module																																																									
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2010	ALL	Powertrain	Rear Drive System																																																									
V	2010	ALL	Powertrain	Transmission Control Module																																																									
V	2010	ALL	Chassis	Electronic Brake Control Module																																																									
V	2010	ALL	Body	Body Control Module																																																									
V	2010	ALL	Body	Digital Radio Receiver																																																									
V	2010	ALL	Body	Driver Door Switch																																																									
V	2010	ALL	Body	Heated Seat Module																																																									
V	2010	ALL	Body	HVAC Control Module Auto																																																									
V	2010	ALL	Body	HVAC Control Module Manual																																																									
V	2010	ALL	Body	Instrument Panel Cluster																																																									
V	2010	ALL	Body	Lift Gate Module																																																									
V	2010	ALL	Body	Park Assist Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
V	2010	ALL	Body	Passenger Door Switch																																																										
V	2010	ALL	Body	Passenger Presence System																																																										
V	2010	ALL	Body	Radio																																																										
V	2010	ALL	Body	Rear HVAC/RSA																																																										
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2010	ALL	Body	Theft Deterrent Module																										V	V	V	V																														
V	2011	ALL	Powertrain	Engine Control Module																																																										
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2011	ALL	Powertrain	Rear Drive System																																																										
V	2011	ALL	Powertrain	Transmission Control Module																																																										
V	2011	ALL	Chassis	Electronic Brake Control Module																																																										
V	2011	ALL	Body	Body Control Module																																																										
V	2011	ALL	Body	Digital Radio Receiver																																																										
V	2011	ALL	Body	Driver Door Switch																																																										
V	2011	ALL	Body	Heated Seat Module																																																										
V	2011	ALL	Body	HVAC Control Module Auto																																																										
V	2011	ALL	Body	HVAC Control Module Manual																																																										
V	2011	ALL	Body	Instrument Panel Cluster																																																										
V	2011	ALL	Body	Lift Gate Module																																																										
V	2011	ALL	Body	Park Assist Module																																																										
V	2011	ALL	Body	Passenger Door Switch																																																										
V	2011	ALL	Body	Passenger Presence System																																																										
V	2011	ALL	Body	Radio																																																										
V	2011	ALL	Body	Rear HVAC/RSA																																																										
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2011	ALL	Body	Theft Deterrent Module																										V	V	V	V																														
V	2012	ALL	Powertrain	Engine Control Module																																																										
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2012	ALL	Powertrain	Rear Drive System																																																										
V	2012	ALL	Powertrain	Transmission Control Module																																																										
V	2012	ALL	Chassis	Electronic Brake Control Module																																																										
V	2012	ALL	Body	Body Control Module																																																										
V	2012	ALL	Body	Digital Radio Receiver																																																										
V	2012	ALL	Body	Driver Door Switch																																																										
V	2012	ALL	Body	Heated Seat Module																																																										
V	2012	ALL	Body	HVAC Control Module Auto																																																										
V	2012	ALL	Body	HVAC Control Module Manual																																																										
V	2012	ALL	Body	Instrument Panel Cluster																																																										
V	2012	ALL	Body	Lift Gate Module																																																										
V	2012	ALL	Body	Park Assist Module																																																										
V	2012	ALL	Body	Passenger Door Switch																																																										
V	2012	ALL	Body	Passenger Presence System																																																										
V	2012	ALL	Body	Radio																																																										
V	2012	ALL	Body	Rear HVAC/RSA																																																										
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2012	ALL	Body	Theft Deterrent Module																										V	V	V	V																														
V	2013	ALL	Powertrain	Engine Control Module																																																										
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2013	ALL	Powertrain	Rear Drive System																																																										
V	2013	ALL	Powertrain	Transmission Control Module																																																										
V	2013	ALL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
V	2013	ALL	Body	Body Control Module																																																										
V	2013	ALL	Body	Digital Radio Receiver																																																										
V	2013	ALL	Body	Driver Door Switch																																																										
V	2013	ALL	Body	Heated Seat Module																																																										
V	2013	ALL	Body	HVAC Control Module Auto																																																										
V	2013	ALL	Body	HVAC Control Module Manual																																																										
V	2013	ALL	Body	Instrument Panel Cluster																																																										
V	2013	ALL	Body	Left Side Object Detection Module																																																										
V	2013	ALL	Body	Lift Gate Module																																																										
V	2013	ALL	Body	Park Assist Module																																																										
V	2013	ALL	Body	Passenger Door Switch																																																										
V	2013	ALL	Body	Passenger Presence System																																																										
V	2013	ALL	Body	Radio																																																										
V	2013	ALL	Body	Rear HVAC/RSA																																																										
V	2013	ALL	Body	Right Side Object Detection Module																																																										
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2013	ALL	Body	Theft Deterrent Module																									V	V	V	V																														
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2014	Traverse	Powertrain	Chassis Control Module																																																										
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2014	Traverse	Chassis	Electronic Brake Control Module																																																										
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2014	Traverse	Body	Passenger Presence Module																																																										
V	2014	Traverse	Body	Instrument Cluster																																																										
V	2014	Traverse	Body	Radio																																																										
V	2014	Traverse	Body	Rear Audio Control Module																																																										
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2014	Traverse	Body	Personal Audio Link Control Module																																																										
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																										
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
V	2014	Traverse	Body	Liftgate Control Module																																											V															
V	2014	Traverse	Body	Seat Memory Control Module	V	V	V																																																							
V	2014	Traverse	Body	Front Seat Heating Control Module																																																										
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2014	Traverse	Body	Parking Assist Control Module																																																										
V	2014	Traverse	Body	Frontview Camera Module																																																										
V	2014	Traverse	Body	Theft Deterrent Module				V	V																																																					
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2015	Traverse	Chassis	Electronic Brake Control Module																																																										
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2015	Traverse	Body	Passenger Presence Module																																																									
V	2015	Traverse	Body	Instrument Cluster																																																									
V	2015	Traverse	Body	Radio																																																									
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																									
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																									
V	2015	Traverse	Body	Liftgate Control Module																																											V															
V	2015	Traverse	Body	Seat Memory Control Module	V	V	V																																																							
V	2015	Traverse	Body	Front Seat Heating Control Module																																																									
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																									
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																									
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																									
V	2015	Traverse	Body	Parking Assist Control Module																																																									
V	2015	Traverse	Body	Frontview Camera Module																																																									
V	2015	Traverse	Body	Theft Deterrent Module				V	V																																																				
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																									
V	2016	Traverse	Chassis	Electronic Brake Control Module																																																									
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																									
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2016	Traverse	Body	Passenger Presence Module																																																									
V	2016	Traverse	Body	Instrument Cluster																																																									
V	2016	Traverse	Body	Radio																																																									
V	2016	Traverse	Body	Rear Audio Control Module																																																									
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																									
V	2016	Traverse	Body	Personal Audio Link Control Module																																																									
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																									
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																									
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																									
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																									
V	2016	Traverse	Body	Liftgate Control Module																																											V															
V	2016	Traverse	Body	Seat Memory Control Module	V	V	V																																																							
V	2016	Traverse	Body	Front Seat Heating Control Module																																																									
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																									
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																									
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																									
V	2016	Traverse	Body	Parking Assist Control Module																																																									
V	2016	Traverse	Body	Frontview Camera Module																																																									
V	2016	Traverse	Body	Theft Deterrent Module				V	V																																																				
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																									
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2011	Orlando	Chassis	Parking Brake Control Module																																																										
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2011	Orlando	Chassis	Power Steering Control Module																																																										
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2011	Orlando	Body	Body Control Module																																																										
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2011	Orlando	Body	Instrument Cluster																																																										
A	2011	Orlando	Body	Trailer Interface Control Module																																																										
A	2011	Orlando	Body	Radio																																																										
A	2011	Orlando	Body	Multimedia Player Interface Module																																																										
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
A	2011	Orlando	Body	Keyless Entry Control Module																																																										
A	2011	Orlando	Body	Parking Assist Control Module																																																										
A	2011	Orlando	Body	Steering Column Lock Control Module																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																															
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																										
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2012	Orlando	Chassis	Parking Brake Control Module																																																										
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2012	Orlando	Chassis	Power Steering Control Module																																																										
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2012	Orlando	Body	Body Control Module																																																										
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2012	Orlando	Body	Instrument Cluster																																																										
A	2012	Orlando	Body	Trailer Interface Control Module																																																										
A	2012	Orlando	Body	Radio																																																										
A	2012	Orlando	Body	Multimedia Player Interface Module																																																										
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
A	2012	Orlando	Body	Keyless Entry Control Module																																																										
A	2012	Orlando	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2012	Orlando	Body	Steering Column Lock Control Module																																																									
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																									
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																									
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																														
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																									
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																									
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																									
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																									
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																									
A	2013	Orlando	Chassis	Parking Brake Control Module																																																									
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2013	Orlando	Chassis	Power Steering Control Module																																																									
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2013	Orlando	Body	Body Control Module																																																								
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2013	Orlando	Body	Instrument Cluster																																																								
A	2013	Orlando	Body	Radio																																																								
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																								
A	2013	Orlando	Body	Multimedia Player Interface Module																																																									
A	2013	Orlando	Body	Mobile Telephone Control Module																																																									
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
A	2013	Orlando	Body	Front Seat Heating Control Module																																																									
A	2013	Orlando	Body	Keyless Entry Control Module																																																									
A	2013	Orlando	Body	Parking Assist Control Module																																																									
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																									
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission										V																																														
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	Orlando	Chassis	Power Steering Control Module																																																										
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	Orlando	Body	Body Control Module																																																										
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	Orlando	Body	Instrument Cluster																																																										
A	2014	Orlando	Body	Radio																																																										
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2014	Orlando	Body	Multimedia Player Interface Module																																																										
A	2014	Orlando	Body	Mobile Telephone Control Module																																																										
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2014	Orlando	Body	Front Seat Heating Control Module																																																										
A	2014	Orlando	Body	Rear Seat Heating Control Module																																																										
A	2014	Orlando	Body	Keyless Entry Control Module																																																										
A	2014	Orlando	Body	Parking Assist Control Module																																																										
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission										V																																															
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																															
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	Orlando	Chassis	Power Steering Control Module																																																										
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	Orlando	Body	Body Control Module																																																										
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	Orlando	Body	Instrument Cluster																																																										
A	2015	Orlando	Body	Radio																																																										
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2015	Orlando	Body	Mobile Telephone Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																								
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																								
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																								
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																								
A	2015	Orlando	Body	Front Seat Heating Control Module																																																								
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																								
A	2015	Orlando	Body	Keyless Entry Control Module																																																								
A	2015	Orlando	Body	Parking Assist Control Module																																																								
A	2015	Orlando	Body	Frontview Camera Module																																																								
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																								
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																								
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																								
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																								
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																								
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																								
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																								
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																								
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2016	Orlando	Chassis	Power Steering Control Module																																																								
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2016	Orlando	Body	Body Control Module																																																								
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2016	Orlando	Body	Instrument Cluster																																																								
A	2016	Orlando	Body	Radio																																																								
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																								
A	2016	Orlando	Body	Multimedia Player Interface Module																																																								
A	2016	Orlando	Body	Mobile Telephone Control Module																																																								
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																								
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																								
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																								
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																								
A	2016	Orlando	Body	Front Seat Heating Control Module																																																								
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																								
A	2016	Orlando	Body	Keyless Entry Control Module																																																								
A	2016	Orlando	Body	Parking Assist Control Module																																																								
A	2016	Orlando	Body	Frontview Camera Module																																																								
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module										V																																														
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module										V																																														
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module										V																																														
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module										V																																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module										V																																																
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module										V																																																
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2009	N200	Chassis	Electronic Brake Control Module																																																										
C	2009	N200	Body	Supplemental Inflatable Restraint																																																										
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2009	N300	Chassis	Electronic Brake Control Module																																																										
C	2009	N300	Body	Supplemental Inflatable Restraint																																																										
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2010	N200	Chassis	Electronic Brake Control Module																																																										
C	2010	N200	Body	Supplemental Inflatable Restraint																																																										
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2010	N300	Chassis	Electronic Brake Control Module																																																										
C	2010	N300	Body	Supplemental Inflatable Restraint																																																										
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2011	N200	Chassis	Electronic Brake Control Module																																																										
C	2011	N200	Body	Supplemental Inflatable Restraint																																																										
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2011	N300	Chassis	Electronic Brake Control Module																																																										
C	2011	N300	Body	Supplemental Inflatable Restraint																																																										
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2012	N200	Chassis	Electronic Brake Control Module																																																										
C	2012	N200	Body	Supplemental Inflatable Restraint																																																										
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2012	N300	Chassis	Electronic Brake Control Module																																																										
C	2012	N300	Body	Supplemental Inflatable Restraint																																																										
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module										V																																															
C	2013	N300	Chassis	Electronic Brake Control Module																																																										
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module										V																																															
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																																										
C	2014	N300	Chassis	Electronic Brake Control Module																																																										
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module										V																																															
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																																										
C	2015	Max	Chassis	Electronic Brake Control Module																																																										
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module										V																																															
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																																										
C	2015	Move	Chassis	Electronic Brake Control Module																																																										
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module										V																																															
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																																										
C	2015	N300	Chassis	Electronic Brake Control Module																																																										
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module										V																																															
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																																									
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																																									
C	2016	Max	Chassis	Electronic Brake Control Module																																																									
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module										V																																															
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																																									
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																																									
C	2016	Move	Chassis	Electronic Brake Control Module																																																									
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module										V																																															
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																																									
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																																									
C	2016	N300	Chassis	Electronic Brake Control Module																																																									
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																									
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																									
M	2015	City Express	Chassis	Electronic Brake Control Module																																																									
M	2015	City Express	Chassis	Power Steering Control Module																																																									
M	2015	City Express	Body	Body Control Module																																																									
M	2015	City Express	Body	Underhood Fuse Block																																																									
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2015	City Express	Body	Instrument Cluster																																																									
M	2015	City Express	Body	Tire Pressure Indicator Module																																																									
M	2015	City Express	Body	Radio																																																									
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																									
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																									
M	2016	City Express	Chassis	Electronic Brake Control Module																																																									
M	2016	City Express	Chassis	Power Steering Control Module																																																									
M	2016	City Express	Body	Body Control Module																																																									
M	2016	City Express	Body	Underhood Fuse Block																																																									
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2016	City Express	Body	Instrument Cluster																																																									
M	2016	City Express	Body	Tire Pressure Indicator Module																																																									
M	2016	City Express	Body	Radio																																																									
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																															
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																									
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2011	Orlando	Chassis	Parking Brake Control Module																																																									
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2011	Orlando	Chassis	Power Steering Control Module																																																									
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
P	2011	Orlando	Body	Body Control Module																																																										
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2011	Orlando	Body	Instrument Cluster																																																										
P	2011	Orlando	Body	Trailer Interface Control Module																																																										
P	2011	Orlando	Body	Radio																																																										
P	2011	Orlando	Body	Multimedia Player Interface Module																																																										
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
P	2011	Orlando	Body	Keyless Entry Control Module																																																										
P	2011	Orlando	Body	Parking Assist Control Module																																																										
P	2011	Orlando	Body	Steering Column Lock Control Module																																																										
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																															
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																										
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																										
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																										
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																										
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2012	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2012	Orlando	Chassis	Parking Brake Control Module																																																										
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2012	Orlando	Chassis	Power Steering Control Module																																																										
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2012	Orlando	Body	Body Control Module																																																										
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2012	Orlando	Body	Instrument Cluster																																																										
P	2012	Orlando	Body	Trailer Interface Control Module																																																										
P	2012	Orlando	Body	Radio																																																										
P	2012	Orlando	Body	Multimedia Player Interface Module																																																										
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
P	2012	Orlando	Body	Keyless Entry Control Module																																																										
P	2012	Orlando	Body	Parking Assist Control Module																																																										
P	2012	Orlando	Body	Steering Column Lock Control Module																																																										
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																									
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																														
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																									
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2013	Orlando	Chassis	Parking Brake Control Module																																																									
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2013	Orlando	Chassis	Power Steering Control Module																																																									
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2013	Orlando	Body	Body Control Module																																																									
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2013	Orlando	Body	Instrument Cluster																																																									
P	2013	Orlando	Body	Radio																																																									
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																									
P	2013	Orlando	Body	Multimedia Player Interface Module																																																									
P	2013	Orlando	Body	Mobile Telephone Control Module																																																									
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
P	2013	Orlando	Body	Front Seat Heating Control Module																																																									
P	2013	Orlando	Body	Keyless Entry Control Module																																																									
P	2013	Orlando	Body	Parking Assist Control Module																																																									
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission										V																																														
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																														
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																									
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
P	2014	Orlando	Chassis	Power Steering Control Module																																																										
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2014	Orlando	Body	Body Control Module																																																										
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2014	Orlando	Body	Instrument Cluster																																																										
P	2014	Orlando	Body	Radio																																																										
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																										
P	2014	Orlando	Body	Multimedia Player Interface Module																																																										
P	2014	Orlando	Body	Mobile Telephone Control Module																																																										
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
P	2014	Orlando	Body	Front Seat Heating Control Module																																																										
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																										
P	2014	Orlando	Body	Keyless Entry Control Module																																																										
P	2014	Orlando	Body	Parking Assist Control Module																																																										
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission										V																																															
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission										V																																															
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2015	Orlando	Chassis	Power Steering Control Module																																																										
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2015	Orlando	Body	Body Control Module																																																										
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2015	Orlando	Body	Instrument Cluster																																																										
P	2015	Orlando	Body	Radio																																																										
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																										
P	2015	Orlando	Body	Mobile Telephone Control Module																																																										
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																										
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
P	2015	Orlando	Body	Front Seat Heating Control Module																																																										
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																										
P	2015	Orlando	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
P	2015	Orlando	Body	Parking Assist Control Module																																																										
P	2015	Orlando	Body	Frontview Camera Module																																																										
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																										
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																										
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2016	Orlando	Chassis	Power Steering Control Module																																																										
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2016	Orlando	Body	Body Control Module																																																										
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2016	Orlando	Body	Instrument Cluster																																																										
P	2016	Orlando	Body	Radio																																																										
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																										
P	2016	Orlando	Body	Multimedia Player Interface Module																																																										
P	2016	Orlando	Body	Mobile Telephone Control Module																																																										
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																																										
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
P	2016	Orlando	Body	Front Seat Heating Control Module																																																										
P	2016	Orlando	Body	Rear Seat Heating Control Module																																																										
P	2016	Orlando	Body	Keyless Entry Control Module																																																										
P	2016	Orlando	Body	Parking Assist Control Module																																																										
P	2016	Orlando	Body	Frontview Camera Module																																																										
U	2004	ALL	Powertrain	Engine Control Module										V																																															
U	2004	ALL	Powertrain	Transmission Control Module											V																																														
U	2004	ALL	Body	Digital Radio Receiver																																																										
U	2004	ALL	Body	Driver Information Center																																																									
U	2004	ALL	Body	Instrument Panel Cluster																																																										
U	2004	ALL	Body	Radio																	V	V																																							
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2004	ALL	Body	Vehicle Theft Deterrent																																																										
U	2005	ALL	Powertrain	Engine Control Module										V																																															
U	2005	ALL	Powertrain	Transmission Control Module																																																										
U	2005	ALL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
U	2005	ALL	Body	Body Control Module																																																										
U	2005	ALL	Body	Disc Player and Video																																																										
U	2005	ALL	Body	Digital Radio Receiver																																																										
U	2005	ALL	Body	HVAC Control Module																																																										
U	2005	ALL	Body	Instrument Panel Cluster																																																										
U	2005	ALL	Body	Left Power Sliding Door Module																																																										
U	2005	ALL	Body	Mobile Digital Media																																																										
U	2005	ALL	Body	Navigation Radio																																																										
U	2005	ALL	Body	Navigation Radio																																																										
U	2005	ALL	Body	Radio																																																										
U	2005	ALL	Body	Right Power Sliding Door Module																																																										
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module										V																																																
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																										
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																										
U	2006	ALL	Chassis	Electronic Brake Control Module																																																										
U	2006	ALL	Body	Body Control Module																																																										
U	2006	ALL	Body	Disc Player and Video																																																										
U	2006	ALL	Body	Digital Radio Receiver																																																										
U	2006	ALL	Body	HVAC Control Module																																																										
U	2006	ALL	Body	Instrument Panel Cluster																																																										
U	2006	ALL	Body	Left Power Sliding Door Module																																																										
U	2006	ALL	Body	Mobile Digital Media																																																										
U	2006	ALL	Body	Navigation Radio																																																										
U	2006	ALL	Body	Navigation Radio																																																										
U	2006	ALL	Body	Radio																																																										
U	2006	ALL	Body	Right Power Sliding Door Module																																																										
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																										
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
U	2007	ALL	Chassis	Electronic Brake Control Module																																																										
U	2007	ALL	Body	Body Control Module																																																										
U	2007	ALL	Body	Digital Radio Receiver																																																										
U	2007	ALL	Body	Disc Player and Video Display																																																										
U	2007	ALL	Body	HVAC Control Module																																																										
U	2007	ALL	Body	Left Power Sliding Door Module																																																										
U	2007	ALL	Body	Mobile Digital Media																																																										
U	2007	ALL	Body	Radio																																																										
U	2007	ALL	Body	Navigation Radio																																																										
U	2007	ALL	Body	Right Power Sliding Door Module																																																										
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																										
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
U	2008	ALL	Chassis	Electronic Brake Control Module																																																										
U	2008	ALL	Body	Body Control Module																																																										
U	2008	ALL	Body	Digital Radio Receiver																																																										
U	2008	ALL	Body	Disc Player and Video Display																																																										
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																										
U	2008	ALL	Body	Left Power Sliding Door Module																																																										
U	2008	ALL	Body	Radio																																																									
U	2008	ALL	Body	Navigation Radio																																																									
U	2008	ALL	Body	Remote Control Door Lock Receiver																																																									
U	2008	ALL	Body	Right Power Sliding Door Module																																																									
U	2009	ALL	Powertrain	Engine Control Module																																																									
U	2009	ALL	Powertrain	Transmission Control Module																																																									
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																									
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																									
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																									
U	2009	ALL	Body	Body Control Module																																																									
U	2009	ALL	Body	Digital Radio Receiver																																																									
U	2009	ALL	Body	Disc Player and Video Display																																																									
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																																									
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																									
U	2009	ALL	Body	Instrument Panel Cluster																																																									
U	2009	ALL	Body	Left Power Sliding Door Module																																																									
U	2009	ALL	Body	Radio																																																									
U	2009	ALL	Body	Remote Control Door Lock Receiver																																																									
U	2009	ALL	Body	Right Power Sliding Door Module																																																									
V	2004	ALL	Powertrain	Engine Data Display										V																																															
V	2004	ALL	Powertrain	Transmission Data Display											V																																														
V	2004	ALL	Body	Digital Radio Receiver																																																									
V	2004	ALL	Body	Driver Information Center																																																									
V	2004	ALL	Body	Instrument Panel Cluster																																																									
V	2004	ALL	Body	Radio																	V	V																																							
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2004	ALL	Body	Vehicle Theft Deterrent																																																									
V	2005	Venture	Powertrain	Engine Control Module										V																																															
V	2005	Venture	Powertrain	Transmission Control Module											V																																														
V	2005	Venture	Body	Digital Radio Receiver																																																									
V	2005	Venture	Body	Driver Information Center																																																									
V	2005	Venture	Body	Instrument Panel Cluster																																																									
V	2005	Venture	Body	Radio																	V	V																																							
V	2005	Venture	Body	Supplemental Inflatable Restraint																																																									
V	2005	Venture	Body	Vehicle Theft Deterrent																																																									
V	2005	Uplander	Powertrain	Engine Control Module										V																																															
V	2005	Uplander	Powertrain	Transmission Control Module																																																									
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																									
V	2005	Uplander	Body	Body Control Module																																																									
V	2005	Uplander	Body	Disc Player and Video																																																									
V	2005	Uplander	Body	Digital Radio Receiver																																																									
V	2005	Uplander	Body	HVAC Control Module																																																									
V	2005	Uplander	Body	Instrument Panel Cluster																																																									
V	2005	Uplander	Body	Left Power Sliding Door Module																																																									
V	2005	Uplander	Body	Mobile Digital Media																																																									
V	2005	Uplander	Body	Navigation Radio																																																									
V	2005	Uplander	Body	Navigation Radio																																																									
V	2005	Uplander	Body	Radio																																																									
V	2005	Uplander	Body	Right Power Sliding Door Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
V	2005	Uplander	Body	Supplemental Inflatable Restraint																																																										
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module										V																																																
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																										
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																										
V	2006	ALL	Chassis	Electronic Brake Control Module																																																										
V	2006	ALL	Body	Body Control Module																																																									
V	2006	ALL	Body	Disc Player and Video																																																									
V	2006	ALL	Body	Digital Radio Receiver																																																									
V	2006	ALL	Body	HVAC Control Module																																																									
V	2006	ALL	Body	Instrument Panel Cluster																																																									
V	2006	ALL	Body	Left Power Sliding Door Module																																																									
V	2006	ALL	Body	Mobile Digital Media																																																									
V	2006	ALL	Body	Navigation Radio																																																									
V	2006	ALL	Body	Navigation Radio																																																									
V	2006	ALL	Body	Radio																																																									
V	2006	ALL	Body	Right Power Sliding Door Module																																																									
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																									
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																									
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																									
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																									
V	2007	ALL	Chassis	Electronic Brake Control Module																																																									
V	2007	ALL	Body	Body Control Module																																																									
V	2007	ALL	Body	Digital Radio Receiver																																																									
V	2007	ALL	Body	Disc Player and Video Display																																																									
V	2007	ALL	Body	HVAC Control Module																																																									
V	2007	ALL	Body	Left Power Sliding Door Module																																																									
V	2007	ALL	Body	Mobile Digital Media																																																									
V	2007	ALL	Body	Radio																																																									
V	2007	ALL	Body	Navigation Radio																																																									
V	2007	ALL	Body	Right Power Sliding Door Module																																																									
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																									
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																									
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																									
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																									
V	2008	ALL	Chassis	Electronic Brake Control Module																																																									
V	2008	ALL	Body	Body Control Module																																																									
V	2008	ALL	Body	Digital Radio Receiver																																																									
V	2008	ALL	Body	Disc Player and Video Display																																																									
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																																									
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																									
V	2008	ALL	Body	Left Power Sliding Door Module																																																									
V	2008	ALL	Body	Radio																																																									
V	2008	ALL	Body	Navigation Radio																																																									
V	2008	ALL	Body	Remote Control Door Lock Receiver																																																									
V	2008	ALL	Body	Right Power Sliding Door Module																																																									
V	2009	ALL	Powertrain	Engine Control Module																																																									
V	2009	ALL	Powertrain	Transmission Control Module																																																									
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																									
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																									
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
V	2009	ALL	Body	Body Control Module																																																										
V	2009	ALL	Body	Digital Radio Receiver																																																										
V	2009	ALL	Body	Disc Player and Video Display																																																										
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																																										
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																										
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																										
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																										
V	2009	ALL	Body	Left Power Sliding Door Module																																																										
V	2009	ALL	Body	Radio																																																										
V	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
V	2009	ALL	Body	Right Power Sliding Door Module																																																										
X	2004	ALL	Powertrain	Engine Control Module										V																																															
X	2004	ALL	Powertrain	Transmission Control Module											V																																														
X	2004	ALL	Body	Digital Radio Receiver																																																										
X	2004	ALL	Body	Driver Information Center																																																										
X	2004	ALL	Body	Instrument Panel Cluster																																																										
X	2004	ALL	Body	Radio																	V	V																																							
X	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
X	2004	ALL	Body	Vehicle Theft Deterrent																																																										
X	2005	ALL	Powertrain	Engine Control Module										V																																															
X	2005	ALL	Powertrain	Transmission Control Module																																																										
X	2005	ALL	Chassis	Electronic Brake Control Module																																																										
X	2005	ALL	Body	Body Control Module																																																										
X	2005	ALL	Body	Disc Player and Video																																																										
X	2005	ALL	Body	Digital Radio Receiver																																																										
X	2005	ALL	Body	HVAC Control Module																																																										
X	2005	ALL	Body	Instrument Panel Cluster																																																										
X	2005	ALL	Body	Left Power Sliding Door Module																																																										
X	2005	ALL	Body	Mobile Digital Media																																																										
X	2005	ALL	Body	Navigation Radio																																																										
X	2005	ALL	Body	Navigation Radio																																																										
X	2005	ALL	Body	Radio																																																										
X	2005	ALL	Body	Right Power Sliding Door Module																																																										
X	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module										V																																															
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
X	2006	ALL	Chassis	Electronic Brake Control Module																																																										
X	2006	ALL	Body	Body Control Module																																																										
X	2006	ALL	Body	Disc Player and Video																																																										
X	2006	ALL	Body	Digital Radio Receiver																																																										
X	2006	ALL	Body	HVAC Control Module																																																										
X	2006	ALL	Body	Instrument Panel Cluster																																																										
X	2006	ALL	Body	Left Power Sliding Door Module																																																										
X	2006	ALL	Body	Mobile Digital Media																																																										
X	2006	ALL	Body	Navigation Radio																																																										
X	2006	ALL	Body	Navigation Radio																																																										
X	2006	ALL	Body	Radio																																																										
X	2006	ALL	Body	Right Power Sliding Door Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																	V																										
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																						V	V																				
A	2006	ALL	Powertrain	Transmission Control Module																																																												
A	2006	ALL	Chassis	Electronic Brake Control Module																																																												
A	2006	ALL	Chassis	Power Steering Control Module																																																												
A	2006	ALL	Body	Body Control Module											V																						V		V							V																		
A	2006	ALL	Body	Digital Radio Receiver																																																											
A	2006	ALL	Body	Instrument Panel Cluster																																																												
A	2006	ALL	Body	Radio																																																												
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
A	2006	ALL	Body	Theft Deterrent Module																																																												
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																								V																				
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																												
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																						V	V																				
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																												
A	2007	ALL	Chassis	Electronic Brake Control Module																																																												
A	2007	ALL	Chassis	Power Steering Control Module																																																												
A	2007	ALL	Body	Body Control Module											V																						V		V							V																		
A	2007	ALL	Body	Digital Radio Receiver																																																											
A	2007	ALL	Body	Instrument Panel Cluster																																																												
A	2007	ALL	Body	Radio																																																												
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
A	2007	ALL	Body	Theft Deterrent Module																																																												
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																								V																				
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																												
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module																																								V																				
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																												
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																						V	V																				
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																												
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES																																									V																		
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2008	HHR	Chassis	Power Steering Control Module																																																												
A	2008	HHR	Chassis	Power Steering Control Module																																																												
A	2008	HHR	Body	Body Control Module											V																						V		V							V																		
A	2008	HHR	Body	Digital Radio Receiver																																																											
A	2008	HHR	Body	Instrument Panel Cluster																																																												
A	2008	HHR	Body	Radio																																																												
A	2008	HHR	Body	Supplemental Inflatable Restraint																																																												
A	2008	HHR	Body	Theft Deterrent Module																																																												
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																								V																				
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																												
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module																																								V																				
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																												
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																						V	V																				
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																												
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																									V																		
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2008	HHR Panel	Body	Body Control Module											V																						V		V							V																		
A	2008	HHR Panel	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																											
A	2008	HHR Panel	Body	Radio																																																											
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																																											
A	2008	HHR Panel	Body	Theft Deterrent Module																																																											
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																																											
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																																											
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																								V																		
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																											
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																											
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																											
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																											
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																											
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																									V																	
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2009	HHR	Chassis	Power Steering Control Module																																																											
A	2009	HHR	Chassis	Power Steering Control Module																																																											
A	2009	HHR	Body	Body Control Module											V																					V		V							V																	
A	2009	HHR	Body	Digital Radio Receiver																																																											
A	2009	HHR	Body	Instrument Panel Cluster																																																											
A	2009	HHR	Body	Radio																																																											
A	2009	HHR	Body	Supplemental Inflatable Restraint																																																											
A	2009	HHR	Body	Theft Deterrent Module																																																											
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																								V																		
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																											
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																											
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																											
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																											
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																											
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																									V																	
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2009	HHR Panel	Body	Body Control Module											V																					V		V							V																	
A	2009	HHR Panel	Body	Digital Radio Receiver																																																											
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																											
A	2009	HHR Panel	Body	Radio																																																											
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																																											
A	2009	HHR Panel	Body	Theft Deterrent Module																																																											
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																											
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																											
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																											
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																											
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																											
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																											
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																									V																	
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2010	HHR	Chassis	Power Steering Control Module																																																											
A	2010	HHR	Chassis	Power Steering Control Module																																																											
A	2010	HHR	Body	Body Control Module											V																					V		V							V																	
A	2010	HHR	Body	Digital Radio Receiver																																																											
A	2010	HHR	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2010	HHR	Body	Radio																																																										
A	2010	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2010	HHR	Body	Theft Deterrent Module																																																										
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																										
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																										
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2010	HHR Panel	Body	Body Control Module											V																					V		V								V																
A	2010	HHR Panel	Body	Digital Radio Receiver																																																										
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2010	HHR Panel	Body	Radio																																																										
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2010	HHR Panel	Body	Theft Deterrent Module																																																										
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																										
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																										
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																										
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																										
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2011	HHR	Chassis	Power Steering Control Module																																																										
A	2011	HHR	Body	Body Control Module											V																					V		V								V																
A	2011	HHR	Body	Digital Radio Receiver																																																										
A	2011	HHR	Body	Instrument Panel Cluster																																																										
A	2011	HHR	Body	Radio																																																										
A	2011	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2011	HHR	Body	Theft Deterrent Module																																																										
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																										
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																										
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																										
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																										
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2011	HHR Panel	Body	Body Control Module											V																					V		V								V																
A	2011	HHR Panel	Body	Digital Radio Receiver																																																										
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2011	HHR Panel	Body	Radio																																																										
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2011	HHR Panel	Body	Theft Deterrent Module																																																										
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																													
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																													
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																													
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																												V																
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																												V																
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																												V																
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																												V																
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																												
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																												
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																												V																
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																												V																
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																												V																
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																												V																
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
A	2013	Trax	Chassis	Electronic Brake Control Module																																																												
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2013	Trax	Chassis	Power Steering Control Module																																																												
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2013	Trax	Body	Body Control Module																																																											
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2013	Trax	Body	Passenger Presence Module																																																												
A	2013	Trax	Body	Instrument Cluster																																																											
A	2013	Trax	Body	Radio																																																											
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																											
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																											
A	2013	Trax	Body	Front Seat Heating Control Module																																																											
A	2013	Trax	Body	Parking Assist Control Module																																																											
A	2013	Trax	Body	Frontview Camera Module																																																											
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																											
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																												V																
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																												V																
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																											V																
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																											
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																											V																
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																												
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
A	2014	Trax	Chassis	Electronic Brake Control Module																																																												
A	2014	Trax	Chassis	Power Steering Control Module																																																												
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2014	Trax	Body	Body Control Module																																																												
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2014	Trax	Body	Passenger Presence Module																																																												
A	2014	Trax	Body	Instrument Cluster																																																												
A	2014	Trax	Body	Radio																																																												
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
A	2014	Trax	Body	Front Seat Heating Control Module																																																												
A	2014	Trax	Body	Parking Assist Control Module																																																												
A	2014	Trax	Body	Frontview Camera Module																																																												
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																												
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																											V																
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																											V																
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																												
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																												
A	2015	Trax	Powertrain	Chassis Control Module																																																												
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
A	2015	Trax	Chassis	Electronic Brake Control Module																																																												
A	2015	Trax	Chassis	Power Steering Control Module																																																												
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2015	Trax	Body	Body Control Module																																																											
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2015	Trax	Body	Passenger Presence Module																																																												
A	2015	Trax	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2015	Trax	Body	Radio																																																												
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																												
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
A	2015	Trax	Body	Seat Memory Control Module																																																												
A	2015	Trax	Body	Front Seat Heating Control Module																																																												
A	2015	Trax	Body	Right Side Object Detection Control Module																																																												
A	2015	Trax	Body	Left Side Object Detection Control Module																																																												
A	2015	Trax	Body	Parking Assist Control Module																																																												
A	2015	Trax	Body	Frontview Camera Module																																																												
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																												
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																												
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																													V															
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																													V															
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																												
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																													V															
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																													V															
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																												
A	2016	Trax	Powertrain	Chassis Control Module																																																												
A	2016	Trax	Chassis	Electronic Brake Control Module																																																												
A	2016	Trax	Chassis	Power Steering Control Module																																																												
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2016	Trax	Body	Body Control Module																																																												
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2016	Trax	Body	Passenger Presence Module																																																												
A	2016	Trax	Body	Instrument Cluster																																																												
A	2016	Trax	Body	Trailer Interface Control Module																																																												
A	2016	Trax	Body	Radio																																																												
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																												
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
A	2016	Trax	Body	Seat Memory Control Module																																																												
A	2016	Trax	Body	Front Seat Heating Control Module																																																												
A	2016	Trax	Body	Right Side Object Detection Control Module																																																												
A	2016	Trax	Body	Left Side Object Detection Control Module																																																												
A	2016	Trax	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2016	Trax	Body	Frontview Camera Module																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																															
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																															
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																															
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																															
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																															
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																																
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																																
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																															
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																															
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																															
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																															
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																															
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																															
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																															
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																															
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																															
C	2004	ALL	Chassis	ESC																																																															
C	2004	ALL	Chassis	Rear Wheel Steering																																																															
C	2004	ALL	Chassis	Tire Pressure Monitor																																																															
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																															
C	2004	ALL	Chassis	VSES																																																															
C	2004	ALL	Body	Amplifier (Bose)																																																															
C	2004	ALL	Body	Body Control Module																																																															
C	2004	ALL	Body	CD Changer																																																															
C	2004	ALL	Body	Chime																																																															
C	2004	ALL	Body	Driver Door Module																																																															
C	2004	ALL	Body	Driver Seat Module																																																															
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																															
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																															
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																															
C	2004	ALL	Body	Instrument Panel Cluster																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2004	ALL	Body	OnStar																																																														
C	2004	ALL	Body	Passenger Door Module																																																														
C	2004	ALL	Body	Passenger Presence System																																																														
C	2004	ALL	Body	Radio Base																																																														
C	2004	ALL	Body	Radio Uplevel																																																														
C	2004	ALL	Body	Radio Navigation																																																														
C	2004	ALL	Body	Rear Aux. Climate Module																																																														
C	2004	ALL	Body	Rear HVAC																																																														
C	2004	ALL	Body	Rear Seat Audio																																																														
C	2004	ALL	Body	Rear Seat Entertainment																																																														
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
C	2004	ALL	Body	Vehicle Theft Deterrent																																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																														
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																															
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																															
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																															
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																															
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																															
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																															
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																															
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																															
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																															
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																															
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																															
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																															
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																															
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																															
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																															
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																															
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																															
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																															
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																															
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																															
C	2005	ALL	Chassis	ESC																																																															
C	2005	ALL	Chassis	Rear Wheel Steering																																																															
C	2005	ALL	Chassis	Tire Pressure Monitor																																																															
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2005	ALL	Chassis	VSES																																																													
C	2005	ALL	Body	Amplifier (Bose)																																																														
C	2005	ALL	Body	Body Control Module																																																														
C	2005	ALL	Body	CD Changer																																																														
C	2005	ALL	Body	Chime																																																														
C	2005	ALL	Body	Disc Player and Video Display																																																															
C	2005	ALL	Body	Driver Door Module																																																															
C	2005	ALL	Body	Driver Seat Module																																																															
C	2005	ALL	Body	Generator Battery Control Module																																																															
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																															
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																															
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																															
C	2005	ALL	Body	Instrument Panel Cluster																																																															
C	2005	ALL	Body	Passenger Door Module																																																															
C	2005	ALL	Body	Passenger Presence System																																																															
C	2005	ALL	Body	Base Radio																																																															
C	2005	ALL	Body	Uplevel Radio																																																															
C	2005	ALL	Body	Navigation Radio																																																															
C	2005	ALL	Body	Rear Aux. Climate Module																																																															
C	2005	ALL	Body	Rear HVAC																																																															
C	2005	ALL	Body	Rear Seat Audio																																																															
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																															
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																															
C	2005	ALL	Body	Vehicle Theft Deterrent																																																															
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																																
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																																
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																																
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																																
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																																
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																																
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																																
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																																
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																																
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																																
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																																
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																																
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																																
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																																
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																																
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																																
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																																
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																																
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																																
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																																

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																													
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																													
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																													
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																													
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																													
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																													
C	2006	ALL	Chassis	ESC																																																													
C	2006	ALL	Chassis	Tire Pressure Monitor																																																													
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																													
C	2006	ALL	Chassis	VSES																																																													
C	2006	ALL	Body	Amplifier (Bose)																																																													
C	2006	ALL	Body	Body Control Module																																																													
C	2006	ALL	Body	CD Changer																																																													
C	2006	ALL	Body	Chime																																																												
C	2006	ALL	Body	Disc Player and Video Display																																																													
C	2006	ALL	Body	Driver Door Module																																																													
C	2006	ALL	Body	Driver Seat Module																																																													
C	2006	ALL	Body	Generator Battery Control Module																																																													
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																													
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																													
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																													
C	2006	ALL	Body	Instrument Panel Cluster																																																													
C	2006	ALL	Body	Passenger Door Module																																																													
C	2006	ALL	Body	Passenger Presence System																																																													
C	2006	ALL	Body	Base Radio																																																													
C	2006	ALL	Body	Uplevel Radio																																																													
C	2006	ALL	Body	Navigation Radio																																																													
C	2006	ALL	Body	Rear Aux. Climate Module																																																													
C	2006	ALL	Body	Rear HVAC																																																													
C	2006	ALL	Body	Rear Seat Audio																																																													
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																													
C	2006	ALL	Body	Vehicle Theft Deterrent																																																													
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																													
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																			
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																			
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																			
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																			
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																														
C	2007	Avalanche	Body	Amplifier (Bose)																																																														
C	2007	Avalanche	Body	Assist Step Controller																																																														
C	2007	Avalanche	Body	Body Control Module																																																														
C	2007	Avalanche	Body	Body Control Module (aux.)																																																														
C	2007	Avalanche	Body	Digital Radio Receiver																																																														
C	2007	Avalanche	Body	Driver Door Switch																																																														
C	2007	Avalanche	Body	HVAC Control Module Auto																																																														
C	2007	Avalanche	Body	HVAC Control Module Manual																																																														
C	2007	Avalanche	Body	Instrument Panel Cluster																																																														
C	2007	Avalanche	Body	Memory Seat Module																																																														
C	2007	Avalanche	Body	Park Assist Module																																																														
C	2007	Avalanche	Body	Passenger Door Switch																																																														
C	2007	Avalanche	Body	Passenger Presence System																																																														
C	2007	Avalanche	Body	Radio																																																														
C	2007	Avalanche	Body	Rear Heated Seat Module																																																														
C	2007	Avalanche	Body	Rear HVAC/RSA																																																														
C	2007	Avalanche	Body	Rollover Sensor																																																														
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																														
C	2007	Avalanche	Body	Theft Deterrent Module																																																														
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																					
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																					
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																					
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																					
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																					
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																														
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																														
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																														
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																														
C	2007	Suburban	Chassis	Electronic Suspension Control																																																														
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																														
C	2007	Suburban	Body	Amplifier (Bose)																																																														
C	2007	Suburban	Body	Assist Step Controller																																																														
C	2007	Suburban	Body	Body Control Module																																																														
C	2007	Suburban	Body	Body Control Module (aux.)																																																														
C	2007	Suburban	Body	Digital Radio Receiver																																																														
C	2007	Suburban	Body	Driver Door Switch																																																														
C	2007	Suburban	Body	HVAC Control Module Auto																																																														
C	2007	Suburban	Body	HVAC Control Module Manual																																																														
C	2007	Suburban	Body	Instrument Panel Cluster																																																														
C	2007	Suburban	Body	Lift Gate Module																																																														
C	2007	Suburban	Body	Memory Seat Module																																																														
C	2007	Suburban	Body	Park Assist Module																																																														
C	2007	Suburban	Body	Passenger Door Switch																																																														
C	2007	Suburban	Body	Passenger Presence System																																																														
C	2007	Suburban	Body	Radio																																																														
C	2007	Suburban	Body	Rear Heated Seat Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2007	Suburban	Body	Rear HVAC/RSA																																																														
C	2007	Suburban	Body	Rollover Sensor																																																															
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																																															
C	2007	Suburban	Body	Theft Deterrent Module																																																															
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																						
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																						
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																															
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																															
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																						
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																															
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																															
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								V																						
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																															
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																						
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																						
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																						
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																															
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																						
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																															
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																															
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																						
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																															
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																															
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																															
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2007	Silverado	Chassis	Electronic Suspension Control																																																															
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																															
C	2007	Silverado	Body	Amplifier (Bose)																																																															
C	2007	Silverado	Body	Body Control Module																																																															
C	2007	Silverado	Body	Body Control Module (aux.)																																																															
C	2007	Silverado	Body	Digital Radio Receiver																																																															
C	2007	Silverado	Body	Driver Door Switch																																																															
C	2007	Silverado	Body	HVAC Control Module Auto																																																															
C	2007	Silverado	Body	HVAC Control Module Manual																																																															
C	2007	Silverado	Body	Instrument Panel Cluster																																																															
C	2007	Silverado	Body	Memory Seat Module																																																															
C	2007	Silverado	Body	Park Assist Module																																																															
C	2007	Silverado	Body	Passenger Door Switch																																																															
C	2007	Silverado	Body	Passenger Presence System																																																															
C	2007	Silverado	Body	Radio																																																															
C	2007	Silverado	Body	Rear Heated Seat Module																																																															
C	2007	Silverado	Body	Rear HVAC/RSA																																																															
C	2007	Silverado	Body	Rollover Sensor																																																															
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																																															
C	2007	Silverado	Body	Theft Deterrent Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																		
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																		
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																		
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2007	Tahoe	Body	Amplifier (Bose)																																																										
C	2007	Tahoe	Body	Assist Step Controller																																																										
C	2007	Tahoe	Body	Body Control Module																																																										
C	2007	Tahoe	Body	Body Control Module (aux.)																																																										
C	2007	Tahoe	Body	Digital Radio Receiver																																																										
C	2007	Tahoe	Body	Driver Door Switch																																																										
C	2007	Tahoe	Body	HVAC Control Module Auto																																																										
C	2007	Tahoe	Body	HVAC Control Module Manual																																																										
C	2007	Tahoe	Body	Instrument Panel Cluster																																																										
C	2007	Tahoe	Body	Lift Gate Module																																																										
C	2007	Tahoe	Body	Memory Seat Module																																																										
C	2007	Tahoe	Body	Park Assist Module																																																										
C	2007	Tahoe	Body	Passenger Door Switch																																																										
C	2007	Tahoe	Body	Passenger Presence System																																																										
C	2007	Tahoe	Body	Radio																																																										
C	2007	Tahoe	Body	Rear Heated Seat Module																																																										
C	2007	Tahoe	Body	Rear HVAC/RSA																																																										
C	2007	Tahoe	Body	Rollover Sensor																																																										
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2007	Tahoe	Body	Theft Deterrent Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																		
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																		
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																		
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																		
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2008	Avalanche	Body	Amplifier (Bose)																																																										
C	2008	Avalanche	Body	Assist Step Controller																																																										
C	2008	Avalanche	Body	Body Control Module																																																										
C	2008	Avalanche	Body	Body Control Module (aux.)																																																										
C	2008	Avalanche	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2008	Avalanche	Body	Driver Door Switch																																																														
C	2008	Avalanche	Body	HVAC Control Module Auto																																																														
C	2008	Avalanche	Body	HVAC Control Module Manual																																																														
C	2008	Avalanche	Body	Instrument Panel Cluster																																																														
C	2008	Avalanche	Body	Memory Seat Module																																																														
C	2008	Avalanche	Body	Park Assist Module																																																														
C	2008	Avalanche	Body	Passenger Door Switch																																																														
C	2008	Avalanche	Body	Passenger Presence System																																																														
C	2008	Avalanche	Body	Radio																																																														
C	2008	Avalanche	Body	Rear Heated Seat Module																																																														
C	2008	Avalanche	Body	Rear HVAC/RSA																																																														
C	2008	Avalanche	Body	Rollover Sensor																																																														
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																														
C	2008	Avalanche	Body	Theft Deterrent Module																																																														
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																					
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																					
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																					
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																					
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																					
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																														
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																															
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2008	Suburban	Chassis	Electronic Suspension Control																																																															
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																															
C	2008	Suburban	Body	Amplifier (Bose)																																																															
C	2008	Suburban	Body	Assist Step Controller																																																															
C	2008	Suburban	Body	Body Control Module																																																															
C	2008	Suburban	Body	Body Control Module (aux.)																																																															
C	2008	Suburban	Body	Digital Radio Receiver																																																															
C	2008	Suburban	Body	Driver Door Switch																																																															
C	2008	Suburban	Body	HVAC Control Module Auto																																																															
C	2008	Suburban	Body	HVAC Control Module Manual																																																															
C	2008	Suburban	Body	Instrument Panel Cluster																																																															
C	2008	Suburban	Body	Lift Gate Module																																																															
C	2008	Suburban	Body	Memory Seat Module																																																															
C	2008	Suburban	Body	Park Assist Module																																																															
C	2008	Suburban	Body	Passenger Door Switch																																																															
C	2008	Suburban	Body	Passenger Presence System																																																															
C	2008	Suburban	Body	Radio																																																															
C	2008	Suburban	Body	Rear Heated Seat Module																																																															
C	2008	Suburban	Body	Rear HVAC/RSA																																																															
C	2008	Suburban	Body	Rollover Sensor																																																															
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																																															

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																			
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																			
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																												
C	2008	Tahoe	Body	Amplifier (Bose)																																																												
C	2008	Tahoe	Body	Assist Step Controller																																																												
C	2008	Tahoe	Body	Body Control Module																																																												
C	2008	Tahoe	Body	Body Control Module (aux.)																																																												
C	2008	Tahoe	Body	Digital Radio Receiver																																																												
C	2008	Tahoe	Body	Driver Door Switch																																																												
C	2008	Tahoe	Body	HVAC Control Module Auto																																																												
C	2008	Tahoe	Body	HVAC Control Module Manual																																																												
C	2008	Tahoe	Body	Instrument Panel Cluster																																																												
C	2008	Tahoe	Body	Memory Seat Module																																																												
C	2008	Tahoe	Body	Park Assist Module																																																												
C	2008	Tahoe	Body	Passenger Presence System																																																												
C	2008	Tahoe	Body	Radio																																																												
C	2008	Tahoe	Body	Rear Heated Seat Module																																																												
C	2008	Tahoe	Body	Rear HVAC/RSA																																																												
C	2008	Tahoe	Body	Rollover Sensor																																																												
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2008	Tahoe	Body	Theft Deterrent Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																			
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2008	Tahoe Hybrid	Body	Body Control Module																																																												
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2008	Tahoe Hybrid	Body	HVAC Control Module																																																												
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2008	Tahoe Hybrid	Body	Memory Seat Module																																																												
C	2008	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																																												

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																															
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																															
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																															
C	2009	Cheyenne	Body	Amplifier (Bose)																																																															
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																															
C	2009	Cheyenne	Body	Digital Radio Receiver																																																															
C	2009	Cheyenne	Body	Driver Door Switch																																																															
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																															
C	2009	Cheyenne	Body	Park Assist Module																																																															
C	2009	Cheyenne	Body	Passenger Door Switch																																																															
C	2009	Cheyenne	Body	Passenger Presence System																																																															
C	2009	Cheyenne	Body	Rear Heated Seat Module																																																															
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																															
C	2009	Cheyenne	Body	Rollover Sensor																																																															
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																															
C	2009	Cheyenne	Body	Theft Deterrent Module																																																															
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																						
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																						
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																						
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																															
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																															
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																						
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																															
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																						
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																															
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																															
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								V																						
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
C	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																															
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2009	Suburban	Chassis	Electronic Suspension Control																																																															
C	2009	Suburban	Chassis	Trailer Brake Control Module																																																															
C	2009	Suburban	Body	Amplifier (Bose)																																																															
C	2009	Suburban	Body	Assist Step Controller																																																															
C	2009	Suburban	Body	Body Control Module																																																															
C	2009	Suburban	Body	Body Control Module (aux.)																																																															
C	2009	Suburban	Body	Digital Radio Receiver																																																															
C	2009	Suburban	Body	Driver Door Switch																																																															
C	2009	Suburban	Body	HVAC Control Module Auto																																																															
C	2009	Suburban	Body	HVAC Control Module Manual																																																															
C	2009	Suburban	Body	Instrument Panel Cluster																																																															
C	2009	Suburban	Body	Left Side Object Detection Module																																																															
C	2009	Suburban	Body	Lift Gate Module																																																															
C	2009	Suburban	Body	Memory Seat Module																																																															
C	2009	Suburban	Body	Park Assist Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2009	Suburban	Body	Passenger Door Switch																																																														
C	2009	Suburban	Body	Passenger Presence System																																																														
C	2009	Suburban	Body	Radio																																																														
C	2009	Suburban	Body	Rear Heated Seat Module																																																														
C	2009	Suburban	Body	Rear HVAC/RSA																																																														
C	2009	Suburban	Body	Right Side Object Detection Module																																																														
C	2009	Suburban	Body	Rollover Sensor																																																														
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																																														
C	2009	Suburban	Body	Theft Deterrent Module																																																														
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																					
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																					
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																														
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																					
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																														
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																														
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																					
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																														
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																														
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																					
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								V																					
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																														
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																					
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																														
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																					
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																														
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																														
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								V																					
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																					
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																														
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																														
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																														
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																														
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																														
C	2009	Silverado	Chassis	Electronic Suspension Control																																																														
C	2009	Silverado	Chassis	Trailer Brake Control Module																																																														
C	2009	Silverado	Body	Amplifier (Bose)																																																														
C	2009	Silverado	Body	Body Control Module																																																														
C	2009	Silverado	Body	Body Control Module (aux.)																																																														
C	2009	Silverado	Body	Digital Radio Receiver																																																														

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																									V																			
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																									V																			
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																									V																			
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
C	2009	Tahoe	Chassis	Electronic Brake Control Module																																																													
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																													
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																																													
C	2009	Tahoe	Body	Amplifier (Bose)																																																													
C	2009	Tahoe	Body	Assist Step Controller																																																													
C	2009	Tahoe	Body	Body Control Module																																																													
C	2009	Tahoe	Body	Body Control Module (aux.)																																																													
C	2009	Tahoe	Body	Digital Radio Receiver																																																													
C	2009	Tahoe	Body	Driver Door Switch																																																													
C	2009	Tahoe	Body	HVAC Control Module Auto																																																													
C	2009	Tahoe	Body	HVAC Control Module Manual																																																													
C	2009	Tahoe	Body	Instrument Panel Cluster																																																													
C	2009	Tahoe	Body	Left Side Object Detection Module																																																													
C	2009	Tahoe	Body	Lift Gate Module																																																													
C	2009	Tahoe	Body	Memory Seat Module																																																													
C	2009	Tahoe	Body	Park Assist Module																																																													
C	2009	Tahoe	Body	Passenger Door Switch																																																													
C	2009	Tahoe	Body	Passenger Presence System																																																													
C	2009	Tahoe	Body	Radio																																																													
C	2009	Tahoe	Body	Rear Heated Seat Module																																																													
C	2009	Tahoe	Body	Rear HVAC/RSA																																																													
C	2009	Tahoe	Body	Right Side Object Detection Module																																																													
C	2009	Tahoe	Body	Rollover Sensor																																																													
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																													
C	2009	Tahoe	Body	Theft Deterrent Module																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																									V																			
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																													
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																													
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																													
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																													
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																													
C	2009	Tahoe Hybrid	Body	Body Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																															
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																															
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																																															
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																																															
C	2009	Tahoe Hybrid	Body	HVAC Control Module																																																															
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																															
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																															
C	2009	Tahoe Hybrid	Body	Park Assist Module																																																															
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																															
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																																															
C	2009	Tahoe Hybrid	Body	Radio																																																															
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																															
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																															
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																															
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																															
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																															
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																															
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																															
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
C	2010	Avalanche	Chassis	Electronic Brake Control Module																																																															
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																															
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																															
C	2010	Avalanche	Body	Amplifier (Bose)																																																															
C	2010	Avalanche	Body	Assist Step Controller																																																															
C	2010	Avalanche	Body	Body Control Module																																																															
C	2010	Avalanche	Body	Body Control Module (aux.)																																																															
C	2010	Avalanche	Body	Digital Radio Receiver																																																															
C	2010	Avalanche	Body	Driver Door Switch																																																															
C	2010	Avalanche	Body	HVAC Control Module Auto																																																															
C	2010	Avalanche	Body	HVAC Control Module Manual																																																															
C	2010	Avalanche	Body	Instrument Panel Cluster																																																															
C	2010	Avalanche	Body	Memory Seat Module																																																															
C	2010	Avalanche	Body	Park Assist Module																																																															
C	2010	Avalanche	Body	Passenger Door Switch																																																															
C	2010	Avalanche	Body	Passenger Presence System																																																															
C	2010	Avalanche	Body	Radio																																																															
C	2010	Avalanche	Body	Rear Heated Seat Module																																																															
C	2010	Avalanche	Body	Rear HVAC/RSA																																																															
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																															
C	2010	Avalanche	Body	Theft Deterrent Module																																																															
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																														
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																														
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																														
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																														
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Cheyenne	Body	Amplifier (Bose)																																																														
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																														
C	2010	Cheyenne	Body	Digital Radio Receiver																																																														
C	2010	Cheyenne	Body	Driver Door Switch																																																														
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																														
C	2010	Cheyenne	Body	Park Assist Module																																																														
C	2010	Cheyenne	Body	Passenger Door Switch																																																														
C	2010	Cheyenne	Body	Passenger Presence System																																																														
C	2010	Cheyenne	Body	Rear Heated Seat Module																																																														
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																														
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																														
C	2010	Cheyenne	Body	Theft Deterrent Module																																																														
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
C	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																														
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																														
C	2010	Suburban	Chassis	Electronic Suspension Control																																																														
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Suburban	Body	Amplifier (Bose)																																																														
C	2010	Suburban	Body	Assist Step Controller																																																														
C	2010	Suburban	Body	Body Control Module																																																														
C	2010	Suburban	Body	Body Control Module (aux.)																																																														
C	2010	Suburban	Body	Digital Radio Receiver																																																														
C	2010	Suburban	Body	Driver Door Switch																																																														
C	2010	Suburban	Body	HVAC Control Module Auto																																																														
C	2010	Suburban	Body	HVAC Control Module Manual																																																														
C	2010	Suburban	Body	Instrument Panel Cluster																																																														
C	2010	Suburban	Body	Left Side Object Detection Module																																																														
C	2010	Suburban	Body	Lift Gate Module																																																														
C	2010	Suburban	Body	Memory Seat Module																																																														
C	2010	Suburban	Body	Park Assist Module																																																														
C	2010	Suburban	Body	Passenger Door Switch																																																														
C	2010	Suburban	Body	Passenger Presence System																																																														
C	2010	Suburban	Body	Radio																																																														
C	2010	Suburban	Body	Rear Heated Seat Module																																																														
C	2010	Suburban	Body	Rear HVAC/RSA																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2010	Suburban	Body	Right Side Object Detection Module																																																														
C	2010	Suburban	Body	Supplemental Inflatable Restraint																																																														
C	2010	Suburban	Body	Theft Deterrent Module																																																														
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																														
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																														
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																														
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																														
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																														
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																				
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																														
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																														
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																														
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																														
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																														
C	2010	Silverado	Chassis	Electronic Suspension Control																																																														
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
C	2010	Silverado	Body	Amplifier (Bose)																																																														
C	2010	Silverado	Body	Body Control Module																																																														
C	2010	Silverado	Body	Body Control Module (aux.)																																																														
C	2010	Silverado	Body	Digital Radio Receiver																																																														
C	2010	Silverado	Body	Driver Door Switch																																																														
C	2010	Silverado	Body	HVAC Control Module Auto																																																														
C	2010	Silverado	Body	HVAC Control Module Manual																																																														
C	2010	Silverado	Body	Instrument Panel Cluster																																																														
C	2010	Silverado	Body	Memory Seat Module																																																														
C	2010	Silverado	Body	Park Assist Module																																																														
C	2010	Silverado	Body	Passenger Door Switch																																																														
C	2010	Silverado	Body	Passenger Presence System																																																														
C	2010	Silverado	Body	Radio																																																														
C	2010	Silverado	Body	Rear Heated Seat Module																																																														
C	2010	Silverado	Body	Rear HVAC/RSA																																																														
C	2010	Silverado	Body	Supplemental Inflatable Restraint																																																														
C	2010	Silverado	Body	Theft Deterrent Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																									V																			
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																												
C	2010	Silverado Hybrid	Body	Body Control Module																																																												
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																												
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																												
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																												
C	2010	Silverado Hybrid	Body	HVAC Control Module																																																												
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
C	2010	Silverado Hybrid	Body	Park Assist Module																																																												
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																												
C	2010	Silverado Hybrid	Body	Passenger Presence System																																																												
C	2010	Silverado Hybrid	Body	Radio																																																												
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																												
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Tahoe	Body	Amplifier (Bose)																																																												
C	2010	Tahoe	Body	Assist Step Controller																																																												
C	2010	Tahoe	Body	Body Control Module																																																												
C	2010	Tahoe	Body	Body Control Module (aux.)																																																												
C	2010	Tahoe	Body	Digital Radio Receiver																																																												
C	2010	Tahoe	Body	Driver Door Switch																																																												
C	2010	Tahoe	Body	HVAC Control Module Auto																																																												
C	2010	Tahoe	Body	HVAC Control Module Manual																																																												
C	2010	Tahoe	Body	Instrument Panel Cluster																																																												
C	2010	Tahoe	Body	Left Side Object Detection Module																																																												
C	2010	Tahoe	Body	Lift Gate Module																																																												
C	2010	Tahoe	Body	Memory Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2010	Tahoe	Body	Park Assist Module																																																														
C	2010	Tahoe	Body	Passenger Door Switch																																																														
C	2010	Tahoe	Body	Passenger Presence System																																																														
C	2010	Tahoe	Body	Radio																																																													
C	2010	Tahoe	Body	Rear Heated Seat Module																																																														
C	2010	Tahoe	Body	Rear HVAC/RSA																																																														
C	2010	Tahoe	Body	Right Side Object Detection Module																																																														
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																														
C	2010	Tahoe	Body	Theft Deterrent Module																																																														
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																					
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																														
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																														
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																														
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																														
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																														
C	2010	Tahoe Hybrid	Body	Body Control Module																																																														
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																														
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																														
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																																														
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																																														
C	2010	Tahoe Hybrid	Body	HVAC Control Module																																																														
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																														
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																														
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																																														
C	2010	Tahoe Hybrid	Body	Park Assist Module																																																														
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																														
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																																														
C	2010	Tahoe Hybrid	Body	Radio																																																														
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																														
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																														
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																														
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																														
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																														
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																														
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2011	Avalanche	Chassis	Electronic Brake Control Module																																																														
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																														
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2011	Avalanche	Body	Amplifier (Bose)																																																															
C	2011	Avalanche	Body	Assist Step Controller																																																															
C	2011	Avalanche	Body	Body Control Module																																																															
C	2011	Avalanche	Body	Body Control Module (aux.)																																																															
C	2011	Avalanche	Body	Digital Radio Receiver																																																															
C	2011	Avalanche	Body	Driver Door Switch																																																															
C	2011	Avalanche	Body	HVAC Control Module Auto																																																															
C	2011	Avalanche	Body	HVAC Control Module Manual																																																															
C	2011	Avalanche	Body	Instrument Panel Cluster																																																															
C	2011	Avalanche	Body	Memory Seat Module																																																															
C	2011	Avalanche	Body	Park Assist Module																																																															
C	2011	Avalanche	Body	Passenger Door Switch																																																															
C	2011	Avalanche	Body	Passenger Presence System																																																															
C	2011	Avalanche	Body	Radio																																																															
C	2011	Avalanche	Body	Rear Heated Seat Module																																																															
C	2011	Avalanche	Body	Rear HVAC/RSA																																																															
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																															
C	2011	Avalanche	Body	Theft Deterrent Module																																																															
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																	V	V	V		V							
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																	V	V	V		V							
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																															
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																	V	V	V		V							
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																	V	V	V		V							
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																															
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																															
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																															
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																															
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																															
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																											V																			
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																											V																			
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																															
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																															
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																															
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																															
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																															
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																															
C	2011	Captiva	Chassis	Electronic Brake Control Module																																																															
C	2011	Captiva	Chassis	Parking Brake Control Module																																																															
C	2011	Captiva	Body	Body Control Module																																																															
C	2011	Captiva	Body	Auxiliary Body Control Module																																																															
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
C	2011	Captiva	Body	Instrument Cluster																																																															
C	2011	Captiva	Body	Headlamp Control Module																																																															
C	2011	Captiva	Body	HVAC Control Module																																																															
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																															
C	2011	Captiva	Body	Parking Assist Control Module																																																															
C	2011	Captiva	Body	Theft Deterrent Module																																																															
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																													
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																													
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																													
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																													
C	2011	Cheyenne	Body	Amplifier (Bose)																																																													
C	2011	Cheyenne	Body	Body Control Module																																																													
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																													
C	2011	Cheyenne	Body	Digital Radio Receiver																																																													
C	2011	Cheyenne	Body	Driver Door Switch																																																													
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																													
C	2011	Cheyenne	Body	Park Assist Module																																																													
C	2011	Cheyenne	Body	Passenger Door Switch																																																													
C	2011	Cheyenne	Body	Passenger Presence System																																																													
C	2011	Cheyenne	Body	Rear Heated Seat Module																																																													
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																													
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																													
C	2011	Cheyenne	Body	Theft Deterrent Module																																																													
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																													
C	2011	Suburban	Chassis	Electronic Suspension Control																																																													
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																													
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																													
C	2011	Suburban	Body	Amplifier (Bose)																																																													
C	2011	Suburban	Body	Assist Step Controller																																																													
C	2011	Suburban	Body	Body Control Module																																																													
C	2011	Suburban	Body	Body Control Module (aux.)																																																													
C	2011	Suburban	Body	Digital Radio Receiver																																																													
C	2011	Suburban	Body	Driver Door Switch																																																													
C	2011	Suburban	Body	HVAC Control Module Auto																																																													
C	2011	Suburban	Body	HVAC Control Module Manual																																																													
C	2011	Suburban	Body	Instrument Panel Cluster																																																													
C	2011	Suburban	Body	Left Side Object Detection Module																																																													
C	2011	Suburban	Body	Lift Gate Module																																																													
C	2011	Suburban	Body	Memory Seat Module																																																													
C	2011	Suburban	Body	Park Assist Module																																																													
C	2011	Suburban	Body	Passenger Door Switch																																																													
C	2011	Suburban	Body	Passenger Presence System																																																													
C	2011	Suburban	Body	Radio																																																													
C	2011	Suburban	Body	Rear Heated Seat Module																																																													
C	2011	Suburban	Body	Rear HVAC/RSA																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2011	Suburban	Body	Right Side Object Detection Module																																																														
C	2011	Suburban	Body	Supplemental Inflatable Restraint																																																														
C	2011	Suburban	Body	Theft Deterrent Module																																																														
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																														
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																														
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																														
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																														
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																														
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																									V																					
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																														
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																														
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																														
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																									V																					
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																														
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																														
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																														
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																														
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																														
C	2011	Silverado	Chassis	Electronic Suspension Control																																																														
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
C	2011	Silverado	Body	Amplifier (Bose)																																																														
C	2011	Silverado	Body	Body Control Module																																																														
C	2011	Silverado	Body	Body Control Module (aux.)																																																														
C	2011	Silverado	Body	Digital Radio Receiver																																																														
C	2011	Silverado	Body	Driver Door Switch																																																														
C	2011	Silverado	Body	HVAC Control Module Auto																																																														
C	2011	Silverado	Body	HVAC Control Module Manual																																																														
C	2011	Silverado	Body	Instrument Panel Cluster																																																														
C	2011	Silverado	Body	Memory Seat Module																																																														
C	2011	Silverado	Body	Park Assist Module																																																														
C	2011	Silverado	Body	Passenger Door Switch																																																														
C	2011	Silverado	Body	Passenger Presence System																																																														
C	2011	Silverado	Body	Radio																																																														
C	2011	Silverado	Body	Rear Heated Seat Module																																																														
C	2011	Silverado	Body	Rear HVAC/RSA																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																																															
C	2011	Silverado	Body	Theft Deterrent Module																																																															
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																						
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																													
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																													
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																													
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																													
C	2011	Silverado Hybrid	Body	Body Control Module																																																													
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																												
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																												
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																												
C	2011	Silverado Hybrid	Body	HVAC Control Module																																																												
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
C	2011	Silverado Hybrid	Body	Park Assist Module																																																												
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																												
C	2011	Silverado Hybrid	Body	Passenger Presence System																																																												
C	2011	Silverado Hybrid	Body	Radio																																																												
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																												
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2011	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
C	2011	Tahoe	Body	Amplifier (Bose)																																																												
C	2011	Tahoe	Body	Assist Step Controller																																																												
C	2011	Tahoe	Body	Body Control Module																																																												
C	2011	Tahoe	Body	Body Control Module (aux.)																																																												
C	2011	Tahoe	Body	Digital Radio Receiver																																																												
C	2011	Tahoe	Body	Driver Door Switch																																																												
C	2011	Tahoe	Body	HVAC Control Module Auto																																																												
C	2011	Tahoe	Body	HVAC Control Module Manual																																																												
C	2011	Tahoe	Body	Instrument Panel Cluster																																																												
C	2011	Tahoe	Body	Left Side Object Detection Module																																																												
C	2011	Tahoe	Body	Lift Gate Module																																																												
C	2011	Tahoe	Body	Memory Seat Module																																																												
C	2011	Tahoe	Body	Park Assist Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2011	Tahoe	Body	Passenger Door Switch																																																														
C	2011	Tahoe	Body	Passenger Presence System																																																														
C	2011	Tahoe	Body	Radio																																																														
C	2011	Tahoe	Body	Rear Heated Seat Module																																																														
C	2011	Tahoe	Body	Rear HVAC/RSA																																																														
C	2011	Tahoe	Body	Right Side Object Detection Module																																																														
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																														
C	2011	Tahoe	Body	Theft Deterrent Module																																																														
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																					
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																														
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																														
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																														
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																														
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																														
C	2011	Tahoe Hybrid	Body	Body Control Module																																																														
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																														
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																														
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																																														
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																																														
C	2011	Tahoe Hybrid	Body	HVAC Control Module																																																														
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																														
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																														
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																																														
C	2011	Tahoe Hybrid	Body	Park Assist Module																																																														
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																														
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																																														
C	2011	Tahoe Hybrid	Body	Radio																																																														
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																														
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																														
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																														
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																														
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																														
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																														
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2012	Avalanche	Chassis	Electronic Brake Control Module																																																														
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																														
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																														
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2012	Avalanche	Body	Amplifier (Bose)																																																														
C	2012	Avalanche	Body	Assist Step Controller																																																														
C	2012	Avalanche	Body	Body Control Module																																																														
C	2012	Avalanche	Body	Body Control Module (aux.)																																																														
C	2012	Avalanche	Body	Digital Radio Receiver																																																														
C	2012	Avalanche	Body	Driver Door Switch																																																														
C	2012	Avalanche	Body	HVAC Control Module Auto																																																														
C	2012	Avalanche	Body	HVAC Control Module Manual																																																														
C	2012	Avalanche	Body	Instrument Panel Cluster																																																														
C	2012	Avalanche	Body	Memory Seat Module																																																														
C	2012	Avalanche	Body	Navigation Radio																																																														
C	2012	Avalanche	Body	Park Assist Module																																																														
C	2012	Avalanche	Body	Passenger Door Switch																																																														
C	2012	Avalanche	Body	Passenger Presence System																																																														
C	2012	Avalanche	Body	Radio																																																														
C	2012	Avalanche	Body	Rear Heated Seat Module																																																														
C	2012	Avalanche	Body	Rear HVAC/RSA																																																														
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																														
C	2012	Avalanche	Body	Theft Deterrent Module																																																														
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																V	V	V		V								
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																V	V	V		V								
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																														
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																V	V	V		V								
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																V	V	V		V								
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																														
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																														
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																														
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																														
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																														
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																										V																			
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																										V																			
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																														
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																														
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																														
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																														
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																														
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																														
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																														
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																														
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																														
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																														
C	2012	Captiva	Chassis	Parking Brake Control Module																																																														
C	2012	Captiva	Body	Body Control Module																																																														
C	2012	Captiva	Body	Auxiliary Body Control Module																																																														
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2012	Captiva	Body	Instrument Cluster																																																														
C	2012	Captiva	Body	Headlamp Control Module																																																														
C	2012	Captiva	Body	HVAC Control Module																																																														
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																														
C	2012	Captiva	Body	Parking Assist Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2012	Captiva	Body	Theft Deterrent Module																																																														
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																														
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																														
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																														
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																														
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																														
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																														
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																														
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																														
C	2012	Cheyenne	Body	Amplifier (Bose)																																																														
C	2012	Cheyenne	Body	Body Control Module																																																														
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																														
C	2012	Cheyenne	Body	Digital Radio Receiver																																																														
C	2012	Cheyenne	Body	Driver Door Switch																																																														
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																														
C	2012	Cheyenne	Body	Park Assist Module																																																														
C	2012	Cheyenne	Body	Passenger Door Switch																																																														
C	2012	Cheyenne	Body	Passenger Presence System																																																														
C	2012	Cheyenne	Body	Rear Heated Seat Module																																																														
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																														
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																														
C	2012	Cheyenne	Body	Theft Deterrent Module																																																														
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																														
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
C	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																														
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																														
C	2012	Suburban	Chassis	Electronic Suspension Control																																																														
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																														
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																														
C	2012	Suburban	Body	Amplifier (Bose)																																																														
C	2012	Suburban	Body	Assist Step Controller																																																														
C	2012	Suburban	Body	Body Control Module																																																														
C	2012	Suburban	Body	Body Control Module (aux.)																																																														
C	2012	Suburban	Body	Digital Radio Receiver																																																														
C	2012	Suburban	Body	Driver Door Switch																																																														
C	2012	Suburban	Body	HVAC Control Module Auto																																																														
C	2012	Suburban	Body	HVAC Control Module Manual																																																														
C	2012	Suburban	Body	Instrument Panel Cluster																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2012	Suburban	Body	Left Side Object Detection Module																																																														
C	2012	Suburban	Body	Lift Gate Module																																																															
C	2012	Suburban	Body	Memory Seat Module																																																															
C	2012	Suburban	Body	Navigation Radio																																																															
C	2012	Suburban	Body	Park Assist Module																																																															
C	2012	Suburban	Body	Passenger Door Switch																																																															
C	2012	Suburban	Body	Passenger Presence System																																																															
C	2012	Suburban	Body	Radio																																																															
C	2012	Suburban	Body	Rear Heated Seat Module																																																															
C	2012	Suburban	Body	Rear HVAC/RSA																																																															
C	2012	Suburban	Body	Right Side Object Detection Module																																																															
C	2012	Suburban	Body	Supplemental Inflatable Restraint																																																															
C	2012	Suburban	Body	Theft Deterrent Module																																																															
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																															
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																															
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																															
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																															
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																															
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																															
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																															
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																															
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																															
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V																						
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																															
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																															
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																															
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																						
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																															
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																															
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																															
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																															
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																															
C	2012	Silverado	Chassis	Electronic Suspension Control																																																															
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																															
C	2012	Silverado	Body	Amplifier (Bose)																																																															
C	2012	Silverado	Body	Body Control Module																																																															
C	2012	Silverado	Body	Body Control Module (aux.)																																																															
C	2012	Silverado	Body	Digital Radio Receiver																																																															
C	2012	Silverado	Body	Driver Door Switch																																																															
C	2012	Silverado	Body	HVAC Control Module Auto																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2012	Silverado	Body	HVAC Control Module Manual																																																														
C	2012	Silverado	Body	Instrument Panel Cluster																																																														
C	2012	Silverado	Body	Memory Seat Module																																																														
C	2012	Silverado	Body	Navigation Radio																																																														
C	2012	Silverado	Body	Park Assist Module																																																														
C	2012	Silverado	Body	Passenger Door Switch																																																														
C	2012	Silverado	Body	Passenger Presence System																																																														
C	2012	Silverado	Body	Radio																																																														
C	2012	Silverado	Body	Rear Heated Seat Module																																																														
C	2012	Silverado	Body	Rear HVAC/RSA																																																														
C	2012	Silverado	Body	Supplemental Inflatable Restraint																																																														
C	2012	Silverado	Body	Theft Deterrent Module																																																														
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																					
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																														
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																														
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																														
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																														
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																														
C	2012	Silverado Hybrid	Body	Body Control Module																																																														
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																														
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																														
C	2012	Silverado Hybrid	Body	Driver Door Switch																																																														
C	2012	Silverado Hybrid	Body	Heated Seat Module																																																														
C	2012	Silverado Hybrid	Body	HVAC Control Module																																																														
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																														
C	2012	Silverado Hybrid	Body	Navigation Radio																																																														
C	2012	Silverado Hybrid	Body	Park Assist Module																																																														
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																																														
C	2012	Silverado Hybrid	Body	Passenger Presence System																																																														
C	2012	Silverado Hybrid	Body	Radio																																																														
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																														
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																														
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																														
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																														
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																														
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2012	Tahoe	Chassis	Electronic Brake Control Module																																																														
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																														
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																														
C	2012	Tahoe	Body	Amplifier (Bose)																																																														
C	2012	Tahoe	Body	Assist Step Controller																																																														

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																														
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																														
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																														
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2013	Avalanche	Chassis	Electronic Brake Control Module																																																														
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																														
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																														
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																														
C	2013	Avalanche	Body	Amplifier (Bose)																																																														
C	2013	Avalanche	Body	Assist Step Controller																																																														
C	2013	Avalanche	Body	Body Control Module																																																														
C	2013	Avalanche	Body	Body Control Module (aux.)																																																														
C	2013	Avalanche	Body	Digital Radio Receiver																																																														
C	2013	Avalanche	Body	Driver Door Switch																																																														
C	2013	Avalanche	Body	HVAC Control Module Auto																																																														
C	2013	Avalanche	Body	HVAC Control Module Manual																																																														
C	2013	Avalanche	Body	Instrument Panel Cluster																																																														
C	2013	Avalanche	Body	Memory Seat Module																																																														
C	2013	Avalanche	Body	Navigation Radio																																																														
C	2013	Avalanche	Body	Park Assist Module																																																														
C	2013	Avalanche	Body	Passenger Door Switch																																																														
C	2013	Avalanche	Body	Passenger Presence System																																																														
C	2013	Avalanche	Body	Radio																																																														
C	2013	Avalanche	Body	Rear Heated Seat Module																																																														
C	2013	Avalanche	Body	Rear HVAC/RSA																																																														
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																														
C	2013	Avalanche	Body	Theft Deterrent Module																																																														
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																V	V	V		V								
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																V	V	V		V								
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																														
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																V	V	V		V								
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																V	V	V		V								
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																														
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																														
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																														
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																														
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																														
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																														
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																														
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																														
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																														
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																														
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																														
C	2013	Captiva	Chassis	Electronic Brake Control Module																																																														
C	2013	Captiva	Chassis	Parking Brake Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																															
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																															
C	2013	Captiva	Body	Auxiliary Body Control Module																																																															
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
C	2013	Captiva	Body	Instrument Cluster																																																															
C	2013	Captiva	Body	Headlamp Control Module																																																															
C	2013	Captiva	Body	HVAC Control Module																																																															
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																															
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																															
C	2013	Captiva	Body	Theft Deterrent Module																																																															
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																															
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																															
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																															
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																															
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																															
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																															
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																															
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																															
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																															
C	2013	Cheyenne	Body	Amplifier (Bose)																																																															
C	2013	Cheyenne	Body	Body Control Module																																																															
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																															
C	2013	Cheyenne	Body	Digital Radio Receiver																																																															
C	2013	Cheyenne	Body	Driver Door Switch																																																															
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																															
C	2013	Cheyenne	Body	Park Assist Module																																																															
C	2013	Cheyenne	Body	Passenger Door Switch																																																															
C	2013	Cheyenne	Body	Passenger Presence System																																																															
C	2013	Cheyenne	Body	Rear Heated Seat Module																																																															
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																															
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																															
C	2013	Cheyenne	Body	Theft Deterrent Module																																																															
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																															
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																															
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																															
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
C	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																															
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2013	Suburban	Chassis	Electronic Suspension Control																																																															
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																													
C	2013	Suburban	Body	Amplifier (Bose)																																																														
C	2013	Suburban	Body	Assist Step Controller																																																														
C	2013	Suburban	Body	Body Control Module																																																														
C	2013	Suburban	Body	Body Control Module (aux.)																																																														
C	2013	Suburban	Body	Digital Radio Receiver																																																														
C	2013	Suburban	Body	Driver Door Switch																																																														
C	2013	Suburban	Body	HVAC Control Module Auto																																																														
C	2013	Suburban	Body	HVAC Control Module Manual																																																														
C	2013	Suburban	Body	Instrument Panel Cluster																																																														
C	2013	Suburban	Body	Left Side Object Detection Module																																																														
C	2013	Suburban	Body	Lift Gate Module																																																														
C	2013	Suburban	Body	Memory Seat Module																																																														
C	2013	Suburban	Body	Navigation Radio																																																														
C	2013	Suburban	Body	Park Assist Module																																																														
C	2013	Suburban	Body	Passenger Door Switch																																																														
C	2013	Suburban	Body	Passenger Presence System																																																														
C	2013	Suburban	Body	Radio																																																														
C	2013	Suburban	Body	Rear Heated Seat Module																																																														
C	2013	Suburban	Body	Rear HVAC/RSA																																																														
C	2013	Suburban	Body	Right Side Object Detection Module																																																														
C	2013	Suburban	Body	Supplemental Inflatable Restraint																																																														
C	2013	Suburban	Body	Theft Deterrent Module																																																														
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																														
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																														
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																														
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																														
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																														
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																														
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																														
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																														
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V																			
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																													
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																														
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																														
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																														
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																														
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													
C	2013	Silverado	Chassis	Electronic Suspension Control																																																														
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
C	2013	Silverado	Body	Amplifier (Bose)																																																														
C	2013	Silverado	Body	Body Control Module																																																														
C	2013	Silverado	Body	Body Control Module (aux.)																																																														
C	2013	Silverado	Body	Digital Radio Receiver																																																														
C	2013	Silverado	Body	Driver Door Switch																																																														
C	2013	Silverado	Body	HVAC Control Module Auto																																																														
C	2013	Silverado	Body	HVAC Control Module Manual																																																														
C	2013	Silverado	Body	Instrument Panel Cluster																																																														
C	2013	Silverado	Body	Memory Seat Module																																																														
C	2013	Silverado	Body	Navigation Radio																																																														
C	2013	Silverado	Body	Park Assist Module																																																														
C	2013	Silverado	Body	Passenger Door Switch																																																														
C	2013	Silverado	Body	Passenger Presence System																																																														
C	2013	Silverado	Body	Radio																																																														
C	2013	Silverado	Body	Rear Heated Seat Module																																																														
C	2013	Silverado	Body	Rear HVAC/RSA																																																														
C	2013	Silverado	Body	Supplemental Inflatable Restraint																																																														
C	2013	Silverado	Body	Theft Deterrent Module																																																														
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																					
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																														
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																														
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																														
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																														
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																														
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																														
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																														
C	2013	Silverado Hybrid	Body	Body Control Module																																																														
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																														
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																														
C	2013	Silverado Hybrid	Body	Driver Door Switch																																																														
C	2013	Silverado Hybrid	Body	Heated Seat Module																																																														
C	2013	Silverado Hybrid	Body	HVAC Control Module																																																														
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																														
C	2013	Silverado Hybrid	Body	Navigation Radio																																																														
C	2013	Silverado Hybrid	Body	Park Assist Module																																																														
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																																														
C	2013	Silverado Hybrid	Body	Passenger Presence System																																																														
C	2013	Silverado Hybrid	Body	Radio																																																														
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																														
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																														
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																														
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																														
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2013	Tahoe	Chassis	Electronic Brake Control Module																																																														
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																														
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																														
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																														
C	2013	Tahoe	Body	Amplifier (Bose)																																																														
C	2013	Tahoe	Body	Assist Step Controller																																																														
C	2013	Tahoe	Body	Body Control Module																																																														
C	2013	Tahoe	Body	Body Control Module (aux.)																																																														
C	2013	Tahoe	Body	Digital Radio Receiver																																																														
C	2013	Tahoe	Body	Driver Door Switch																																																														
C	2013	Tahoe	Body	HVAC Control Module Auto																																																														
C	2013	Tahoe	Body	HVAC Control Module Manual																																																														
C	2013	Tahoe	Body	Instrument Panel Cluster																																																														
C	2013	Tahoe	Body	Left Side Object Detection Module																																																														
C	2013	Tahoe	Body	Lift Gate Module																																																														
C	2013	Tahoe	Body	Memory Seat Module																																																														
C	2013	Tahoe	Body	Navigation Radio																																																														
C	2013	Tahoe	Body	Park Assist Module																																																														
C	2013	Tahoe	Body	Passenger Door Switch																																																														
C	2013	Tahoe	Body	Passenger Presence System																																																														
C	2013	Tahoe	Body	Radio																																																														
C	2013	Tahoe	Body	Rear Heated Seat Module																																																														
C	2013	Tahoe	Body	Rear HVAC/RSA																																																														
C	2013	Tahoe	Body	Right Side Object Detection Module																																																														
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																														
C	2013	Tahoe	Body	Theft Deterrent Module																																																														
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																					
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																														
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																														
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																														
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																														
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																														
C	2013	Tahoe Hybrid	Body	Body Control Module																																																														
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																														
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																														
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																																														

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																													
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																													
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																													
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																													
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																													
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																													
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																													
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2014	Captiva (Other)	Body	Instrument Cluster																																																													
C	2014	Captiva (Other)	Body	Headlamp Control Module																																																													
C	2014	Captiva (Other)	Body	HVAC Control Module																																																													
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																													
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																													
C	2014	Captiva (Other)	Body	Theft Deterrent Module																																																													
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																													
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																													
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																													
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																													
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																													
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																													
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																													
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																													
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																													
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																													
C	2014	Cheyenne	Chassis	Power Steering Control Module																																																													
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2014	Cheyenne	Body	Body Control Module																																																													
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2014	Cheyenne	Body	Passenger Presence Module																																																													
C	2014	Cheyenne	Body	Instrument Cluster																																																													
C	2014	Cheyenne	Body	Radio Control																																																													
C	2014	Cheyenne	Body	HVAC Control																																																													
C	2014	Cheyenne	Body	Radio																																																													
C	2014	Cheyenne	Body	Amplifier																																																													
C	2014	Cheyenne	Body	Media Disc Player																																																													
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																													
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																													
C	2014	Cheyenne	Body	HVAC Control Module																																																													
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																													
C	2014	Cheyenne	Body	Parking Assist Control Module																																																													
C	2014	Cheyenne	Body	Frontview Camera Module																																																													
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																													
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																													
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																														
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																														
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																														
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																														
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																														
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																														
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
C	2014	Silverado	Chassis	Electronic Brake Control Module																																																														
C	2014	Silverado	Chassis	Parking Brake Control Module																																																														
C	2014	Silverado	Chassis	Power Steering Control Module																																																														
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																														
C	2014	Silverado	Body	Body Control Module																																																														
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2014	Silverado	Body	Passenger Presence Module																																																														
C	2014	Silverado	Body	Instrument Cluster																																																														
C	2014	Silverado	Body	Radio Control																																																													
C	2014	Silverado	Body	HVAC Control																																																													
C	2014	Silverado	Body	Radio																																																													
C	2014	Silverado	Body	Amplifier																																																													
C	2014	Silverado	Body	Media Disc Player																																																													
C	2014	Silverado	Body	Human Machine Interface Control Module																																																													
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																													
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																													
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																													
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																													
C	2014	Silverado	Body	Parking Assist Control Module																																																													
C	2014	Silverado	Body	Frontview Camera Module																																																													
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																													
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																													
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																													
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																													
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																													
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																														V			
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																													
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																													
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																													
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																													
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																													
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																													
C	2014	Silverado HD	Chassis	Suspension Control Module																																																													
C	2014	Silverado HD	Body	Body Control Module																																																													
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2014	Silverado HD	Body	Passenger Presence Module																																																													
C	2014	Silverado HD	Body	Instrument Cluster																																																													
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																													
C	2014	Silverado HD	Body	Base Radio																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2014	Silverado HD	Body	Navigation Radio																																																												
C	2014	Silverado HD	Body	Uplevel Radio																																																												
C	2014	Silverado HD	Body	Amplifier																																																												
C	2014	Silverado HD	Body	Rear Audio Control Module																																																												
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																												
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																												
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																												
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																												
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																												
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																												
C	2014	Silverado HD	Body	Seat Memory Control Module																																																												
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																												
C	2014	Silverado HD	Body	Parking Assist Control Module																																																												
C	2014	Silverado HD	Body	Theft Deterrent Module																																																												
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																												
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																												
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																												
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																												
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																												
C	2014	Suburban	Chassis	Parking Brake Control Module																																																												
C	2014	Suburban	Chassis	Suspension Control Module																																																												
C	2014	Suburban	Body	Body Control Module																																																												
C	2014	Suburban	Body	Auxiliary Body Control Module																																																												
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Suburban	Body	Passenger Presence Module																																																												
C	2014	Suburban	Body	Instrument Cluster																																																												
C	2014	Suburban	Body	Base Radio																																																												
C	2014	Suburban	Body	Navigation Radio																																																												
C	2014	Suburban	Body	Uplevel Radio																																																												
C	2014	Suburban	Body	Amplifier																																																												
C	2014	Suburban	Body	Rear Audio Control Module																																																												
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																												
C	2014	Suburban	Body	Personal Audio Link Control Module																																																												
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																												
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																												
C	2014	Suburban	Body	Liftgate Control Module																																																												
C	2014	Suburban	Body	Seat Memory Control Module																																																												
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2014	Suburban	Body	Assist Step Control Module																																																														
C	2014	Suburban	Body	Right Side Object Detection Control Module																																																														
C	2014	Suburban	Body	Left Side Object Detection Control Module																																																														
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																														
C	2014	Suburban	Body	Parking Assist Control Module																																																														
C	2014	Suburban	Body	Theft Deterrent Module																																																														
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																														
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																														
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																														
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																														
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																														
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																														
C	2014	Tahoe	Chassis	Suspension Control Module																																																														
C	2014	Tahoe	Body	Body Control Module																																																														
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																														
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2014	Tahoe	Body	Passenger Presence Module																																																														
C	2014	Tahoe	Body	Instrument Cluster																																																														
C	2014	Tahoe	Body	Base Radio																																																														
C	2014	Tahoe	Body	Navigation Radio																																																														
C	2014	Tahoe	Body	Uplevel Radio																																																														
C	2014	Tahoe	Body	Amplifier																																																														
C	2014	Tahoe	Body	Rear Audio Control Module																																																														
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																														
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																														
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																														
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																														
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																														
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																														
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																														
C	2014	Tahoe	Body	Liftgate Control Module																																																														
C	2014	Tahoe	Body	Seat Memory Control Module																																																														
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																																														
C	2014	Tahoe	Body	Assist Step Control Module																																																														
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																																														
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																																														
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																														
C	2014	Tahoe	Body	Parking Assist Control Module																																																														
C	2014	Tahoe	Body	Theft Deterrent Module																																																														
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																														
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																														
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																														
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																														
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																														
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																														
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2015	Captiva (3GN)	Body	Body Control Module																																																															
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																																															
C	2015	Captiva (3GN)	Body	Instrument Cluster																																																															
C	2015	Captiva (3GN)	Body	Radio																																																															
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																															
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																															
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																															
C	2015	Captiva (3GN)	Body	HVAC Control Module																																																															
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																															
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																															
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																															
C	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																															
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																														V	V	V		V											
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																														V	V	V		V											
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																															
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																														V	V	V		V											
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																														V	V	V		V											
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																															
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																											V																			
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																											V																			
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																															
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																															
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																															
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																															
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																															
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																															
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																															
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																															
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																															
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																															
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																															
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
C	2015	Captiva (Other)	Body	Instrument Cluster																																																															
C	2015	Captiva (Other)	Body	Headlamp Control Module																																																															
C	2015	Captiva (Other)	Body	HVAC Control Module																																																															
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																															
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																															
C	2015	Captiva (Other)	Body	Theft Deterrent Module																																																															
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																															
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																															
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																															
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																															
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																															
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																															
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																															
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																															
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																															
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																															
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																															
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																											
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																												
C	2015	Cheyenne	Chassis	Power Steering Control Module																																																												
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2015	Cheyenne	Chassis	Suspension Control Module																														V	V																													
C	2015	Cheyenne	Body	Body Control Module																																																												
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Cheyenne	Body	Passenger Presence Module																																																												
C	2015	Cheyenne	Body	Instrument Cluster																																																												
C	2015	Cheyenne	Body	Radio Controls																																																												
C	2015	Cheyenne	Body	HVAC Controls																																																												
C	2015	Cheyenne	Body	Radio																																																												
C	2015	Cheyenne	Body	Amplifier																																																												
C	2015	Cheyenne	Body	Media Disc Player																																																												
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																												
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																												
C	2015	Cheyenne	Body	HVAC Control Module																																																												
C	2015	Cheyenne	Body	Parking Assist Control Module																																																												
C	2015	Cheyenne	Body	Frontview Camera Module																																																												
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																												
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																												
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																												
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																												
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																												
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2015	Silverado	Chassis	Electronic Brake Control Module																																																												
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																												
C	2015	Silverado	Chassis	Power Steering Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2015	Silverado	Chassis	Suspension Control Module																														V	V																													
C	2015	Silverado	Body	Body Control Module																																																											
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Silverado	Body	Passenger Presence Module																																																											
C	2015	Silverado	Body	Instrument Cluster																																																										
C	2015	Silverado	Body	Radio Controls																																																										
C	2015	Silverado	Body	HVAC Controls																																																										
C	2015	Silverado	Body	Radio																																																										
C	2015	Silverado	Body	Amplifier																																																										
C	2015	Silverado	Body	Media Disc Player																																																										
C	2015	Silverado	Body	Human Machine Interface Control Module																																																										
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																										
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2015	Silverado	Body	Parking Assist Control Module																																																										
C	2015	Silverado	Body	Frontview Camera Module																																																										
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Suburban	Chassis	Parking Brake Control Module																																																										
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Suburban	Chassis	Power Steering Control Module																																																										
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Suburban	Chassis	Suspension Control Module																														V	V																												
C	2015	Suburban	Body	Body Control Module																																																										
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Suburban	Body	Passenger Presence Module																																																										
C	2015	Suburban	Body	Instrument Cluster																																																										
C	2015	Suburban	Body	Radio Controls																																																										
C	2015	Suburban	Body	HVAC Controls																																																										
C	2015	Suburban	Body	Radio																																																										
C	2015	Suburban	Body	Amplifier																																																										
C	2015	Suburban	Body	Media Disc Player																																																										
C	2015	Suburban	Body	Human Machine Interface Control Module																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Suburban	Body	HVAC Control Module																																																										
C	2015	Suburban	Body	Liftgate Control Module																																																										
C	2015	Suburban	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2015	Suburban	Body	Assist Step Control Module																																																														
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																														
C	2015	Suburban	Body	Parking Assist Control Module																																																														
C	2015	Suburban	Body	Frontview Camera Module																																																														
C	2015	Suburban	Body	Steering Column Lock Control Module																																																														
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																														
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																														
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																														
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																														
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																														
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																														
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																														
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																														
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																														
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																																														
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																														
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																														
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																														
C	2015	Tahoe	Chassis	Power Steering Control Module																																																														
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																														
C	2015	Tahoe	Chassis	Suspension Control Module																														V	V																															
C	2015	Tahoe	Body	Body Control Module																																																														
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2015	Tahoe	Body	Passenger Presence Module																																																														
C	2015	Tahoe	Body	Instrument Cluster																																																														
C	2015	Tahoe	Body	Radio Controls																																																														
C	2015	Tahoe	Body	HVAC Controls																																																														
C	2015	Tahoe	Body	Radio																																																														
C	2015	Tahoe	Body	Amplifier																																																														
C	2015	Tahoe	Body	Media Disc Player																																																														
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																														
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																														
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																														
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																														
C	2015	Tahoe	Body	HVAC Control Module																																																														
C	2015	Tahoe	Body	Liftgate Control Module																																																														
C	2015	Tahoe	Body	Keyless Entry Control Module																																																														
C	2015	Tahoe	Body	Assist Step Control Module																																																														
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																														
C	2015	Tahoe	Body	Parking Assist Control Module																																																														
C	2015	Tahoe	Body	Frontview Camera Module																																																														
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																														
C	2015	Tahoe	Body	Battery Energy Control Module				V	V	V	V																																																						
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																														
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																														
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																														
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																														
C	2016	Captiva (3GN)	Body	Body Control Module																																																														
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																														
C	2016	Captiva (3GN)	Body	Radio																																																														
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																														
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																														
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																														
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																														
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																														
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																														
C	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																														
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																														
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																														
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																														
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																													V	V	V		V											
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																													V	V	V		V											
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																														
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																													V	V	V		V											
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																													V	V	V		V											
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																														
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																											V																		
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																											V																		
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																														
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																													
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																													
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																													
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																													
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																													
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																													
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																													
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																													
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																													
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																													
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	Captiva (Other)	Body	Instrument Cluster																																																													
C	2016	Captiva (Other)	Body	Headlamp Control Module																																																													
C	2016	Captiva (Other)	Body	Radio																																																													
C	2016	Captiva (Other)	Body	HVAC Control Module																																																													
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																													
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																													
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																													
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																													
C	2016	Captiva (Other)	Body	Theft Deterrent Module																																																													
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																													
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																											
C	2016	Cheyenne	Chassis	Power Steering Control Module																																																											
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Cheyenne	Chassis	Suspension Control Module																														V	V																												
C	2016	Cheyenne	Body	Body Control Module																																																											
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Cheyenne	Body	Passenger Presence Module																																																											
C	2016	Cheyenne	Body	Instrument Cluster																																																											
C	2016	Cheyenne	Body	Radio Controls																																																											
C	2016	Cheyenne	Body	HVAC Controls																																																											
C	2016	Cheyenne	Body	Radio																																																											
C	2016	Cheyenne	Body	Amplifier																																																											
C	2016	Cheyenne	Body	Media Disc Player																																																											
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																											
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																											
C	2016	Cheyenne	Body	HVAC Control Module																																																											
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																											
C	2016	Cheyenne	Body	Parking Assist Control Module																																																											
C	2016	Cheyenne	Body	Frontview Camera Module																																																											
C	2016	Cheyenne	Body	Frontview Camera Module																																																											
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																											
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																											
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																											
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2					V	V		V																																																			
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																					V					
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2016	Silverado	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2016	Silverado	Chassis	Power Steering Control Module																																																												
C	2016	Silverado	Chassis	Power Steering Control Module																																																												
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2016	Silverado	Chassis	Suspension Control Module																													V	V																														
C	2016	Silverado	Body	Body Control Module																																																											
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Silverado	Body	Passenger Presence Module																																																												
C	2016	Silverado	Body	Instrument Cluster																																																												
C	2016	Silverado	Body	Radio Controls																																																											
C	2016	Silverado	Body	HVAC Controls																																																											
C	2016	Silverado	Body	Radio (IO3)																																																											
C	2016	Silverado	Body	Radio (IOB)																																																											
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																											
C	2016	Silverado	Body	Amplifier																																																											
C	2016	Silverado	Body	Media Disc Player																																																											
C	2016	Silverado	Body	Human Machine Interface Control Module																																																											
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																											
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																											
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																											
C	2016	Silverado	Body	Parking Assist Control Module																																																											
C	2016	Silverado	Body	Frontview Camera Module																																																											
C	2016	Silverado	Body	Frontview Camera Module																																																											
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2016	Suburban	Chassis	Electronic Brake Control Module																																																											
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																											
C	2016	Suburban	Chassis	Parking Brake Control Module																																																											
C	2016	Suburban	Chassis	Power Steering Control Module																																																											
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Suburban	Chassis	Suspension Control Module																													V	V																													
C	2016	Suburban	Body	Body Control Module																																																											
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Suburban	Body	Passenger Presence Module																																																											
C	2016	Suburban	Body	Instrument Cluster																																																											
C	2016	Suburban	Body	Radio Controls																																																											
C	2016	Suburban	Body	HVAC Controls																																																											
C	2016	Suburban	Body	Radio																																																											
C	2016	Suburban	Body	Amplifier																																																											
C	2016	Suburban	Body	Media Disc Player																																																											
C	2016	Suburban	Body	Human Machine Interface Control Module																																																											
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																																											
C	2016	Suburban	Body	HVAC Control Module																																																											
C	2016	Suburban	Body	Liftgate Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																												
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																													
C	2016	Suburban	Body	Keyless Entry Control Module																																																													
C	2016	Suburban	Body	Assist Step Control Module																																																													
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																													
C	2016	Suburban	Body	Parking Assist Control Module																																																													
C	2016	Suburban	Body	Frontview Camera Module																																																													
C	2016	Suburban	Body	Steering Column Lock Control Module																																																													
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																																													
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																													
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																													
C	2016	Tahoe	Chassis	Power Steering Control Module																																																													
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2016	Tahoe	Chassis	Suspension Control Module																														V	V																														
C	2016	Tahoe	Body	Body Control Module																																																													
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	Tahoe	Body	Passenger Presence Module																																																													
C	2016	Tahoe	Body	Instrument Cluster																																																													
C	2016	Tahoe	Body	Radio Controls																																																													
C	2016	Tahoe	Body	HVAC Controls																																																													
C	2016	Tahoe	Body	Radio																																																													
C	2016	Tahoe	Body	Amplifier																																																													
C	2016	Tahoe	Body	Media Disc Player																																																													
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																													
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																													
C	2016	Tahoe	Body	HVAC Control Module																																																													
C	2016	Tahoe	Body	Liftgate Control Module																																																													
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																													
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																													
C	2016	Tahoe	Body	Keyless Entry Control Module																																																													
C	2016	Tahoe	Body	Assist Step Control Module																																																													
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																													
C	2016	Tahoe	Body	Parking Assist Control Module																																																													
C	2016	Tahoe	Body	Frontview Camera Module																																																													
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																													
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																													
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																													
E	2004	ALL	Chassis	Electronic Brake Control Module																																																													
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																													
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																													
E	2006	ALL	Chassis	Electronic Brake Control Module																																																													
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																													
E	2007	ALL	Chassis	Electronic Brake Control Module																																																													
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																														
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																														
G	2004	Express/Savana	Chassis	VSES																																																														
G	2004	Express/Savana	Body	Body Control Module																																																														
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																														
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																														
G	2004	Express/Savana	Body	OnStar																																																														
G	2004	Express/Savana	Body	Base Radio																																																														
G	2004	Express/Savana	Body	Uplevel Radio																																																														
G	2004	Express/Savana	Body	Remote Function Actuation																																																														
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																														
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																															
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																														
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																														
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																														
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																														
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																														
G	2004	Express Access/Savana Pro	Chassis	VSES																																																														
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																														
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																														
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																														
G	2004	Express Access/Savana Pro	Body	OnStar																																																														
G	2004	Express Access/Savana Pro	Body	Base Radio																																																														
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																														
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																														
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																														
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																														
G	2005	Express/Savana	Chassis	VSES																																																														
G	2005	Express/Savana	Body	Body Control Module																																																														
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																														
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																														
G	2005	Express/Savana	Body	Base Radio																																																														
G	2005	Express/Savana	Body	Uplevel Radio																																																														
G	2005	Express/Savana	Body	Remote Function Actuation																																																														
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																														
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																														
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																														
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																														
G	2005	Express Access/Savana Pro	Chassis	VSES																																																														
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																														
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																														
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																														
G	2005	Express Access/Savana Pro	Body	Base Radio																																																														
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																														
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																														
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																														
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																														
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																														
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																														
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																												
G	2006	Express/Savana	Chassis	VSES																																																												
G	2006	Express/Savana	Body	Body Control Module																																																												
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																												
G	2006	Express/Savana	Body	Passenger Presence System																																																												
G	2006	Express/Savana	Body	Base Radio																																																												
G	2006	Express/Savana	Body	Uplevel Radio																																																												
G	2006	Express/Savana	Body	Remote Function Actuation																																																												
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
G	2006	Express Access/Savana Pro	Chassis	VSES																																																												
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2006	Express Access/Savana Pro	Body	Base Radio																																																												
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																												
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																													
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																		
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																												
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2007	Express Access/Savana Pro	Body	Radio																																																												
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																		
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																		
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								V																		
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																		
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																		
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2008	Express/Savana	Body	Body Control Module																																																												
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2008	Express/Savana	Body	Passenger Presence System																																																												
G	2008	Express/Savana	Body	Radio																																																											
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2008	Express/Savana	Body	Rollover Sensor																																																												
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2008	Express/Savana	Body	Theft Deterrent Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																		
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																		
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								V																		
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																		

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																														
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																				
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																													
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																													
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																													
G	2008	Express Access/Savana Pro	Body	Radio																																																													
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																													
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																													
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																													
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																				
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																				
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								V																				
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																													
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																				
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2009	Express/Savana	Body	Body Control Module																																																													
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2009	Express/Savana	Body	Passenger Presence System																																																													
G	2009	Express/Savana	Body	Radio																																																													
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
G	2009	Express/Savana	Body	Rollover Sensor																																																													
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
G	2009	Express/Savana	Body	Theft Deterrent Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																				
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																				
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								V																				
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																				
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																													
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																													
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																													
G	2009	Express Access/Savana Pro	Body	Radio																																																													
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																													
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																													
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																													
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																			
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																			
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2010	Express/Savana	Body	Body Control Module																																																													
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2010	Express/Savana	Body	Passenger Presence System																																																													
G	2010	Express/Savana	Body	Radio																																																												
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
G	2010	Express/Savana	Body	Rollover Sensor																																																												
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2010	Express/Savana	Body	Theft Deterrent Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																			
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																		
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2010	Express Access/Savana Pro	Body	Radio																																																										
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																		
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2011	Express/Savana	Body	Body Control Module																																																										
G	2011	Express/Savana	Body	Digital Radio Receiver																																																										
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2011	Express/Savana	Body	Passenger Presence System																																																										
G	2011	Express/Savana	Body	Radio																																																										
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2011	Express/Savana	Body	Rollover Sensor																																																										
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2011	Express/Savana	Body	Theft Deterrent Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																		
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2011	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2011	Express Access/Savana Pro	Body	Radio																																																										
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																		
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2012	Express/Savana	Body	Body Control Module																																																										
G	2012	Express/Savana	Body	Digital Radio Receiver																																																										
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2012	Express/Savana	Body	Passenger Presence System																																																										
G	2012	Express/Savana	Body	Radio																																																										
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2012	Express/Savana	Body	Rollover Sensor																																																										
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2012	Express/Savana	Body	Theft Deterrent Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																		
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2012	Express Access/Savana Pro	Body	Radio																																																										
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																		
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2013	Express/Savana	Body	Body Control Module																																																										
G	2013	Express/Savana	Body	Digital Radio Receiver																																																										
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2013	Express/Savana	Body	Navigation Radio																																																										
G	2013	Express/Savana	Body	Park Assist Module																																																										
G	2013	Express/Savana	Body	Passenger Presence System																																																										
G	2013	Express/Savana	Body	Radio																																																										
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2013	Express/Savana	Body	Rollover Sensor																																																										
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2013	Express/Savana	Body	Theft Deterrent Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																													
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																													
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																			
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2013	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																												
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																												
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2013	Express Access/Savana Pro	Body	Radio																																																												
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																													
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																													
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																													
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																													
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																													
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																													
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																													
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																													
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																													
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																													
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																													
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																													
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
G	2014	Express	Chassis	Electronic Brake Control Module																																																													
G	2014	Express	Body	Body Control Module																																																												
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
G	2014	Express	Body	Passenger Presence Module																																																													
G	2014	Express	Body	Rollover Sensor Module																																																													
G	2014	Express	Body	Instrument Cluster																																																												
G	2014	Express	Body	Chime Alarm Control Module																																																												
G	2014	Express	Body	Base Radio																																																												
G	2014	Express	Body	Navigation Radio																																																												
G	2014	Express	Body	Uplevel Radio																																																												
G	2014	Express	Body	Digital Radio Receiver Control Module																																																												
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																												
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																												
G	2014	Express	Body	Auxiliary Heater Control Module																																																												
G	2014	Express	Body	Remote Control Door Lock Receiver																																																												
G	2014	Express	Body	Parking Assist Control Module																																																												
G	2014	Express	Body	Theft Deterrent Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																													
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																														
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																														
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																														
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																														
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																														
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																														
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																														
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																														
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																														
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																														V			
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																														
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																														
G	2014	Savana	Chassis	Electronic Brake Control Module																																																														
G	2014	Savana	Body	Body Control Module																																																														
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
G	2014	Savana	Body	Passenger Presence Module																																																														
G	2014	Savana	Body	Rollover Sensor Module																																																														
G	2014	Savana	Body	Instrument Cluster																																																														
G	2014	Savana	Body	Chime Alarm Control Module																																																														
G	2014	Savana	Body	Base Radio																																																														
G	2014	Savana	Body	Navigation Radio																																																														
G	2014	Savana	Body	Uplevel Radio																																																														
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																														
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																														
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																														
G	2014	Savana	Body	Auxiliary Heater Control Module																																																														
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																														
G	2014	Savana	Body	Parking Assist Control Module																																																														
G	2014	Savana	Body	Theft Deterrent Module																																																														
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																														
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																														
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																														
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																														
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																														
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																												V			
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																														
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																														
G	2015	Express	Chassis	Electronic Brake Control Module																																																														
G	2015	Express	Body	Body Control Module																																																														
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
G	2015	Express	Body	Rollover Sensor Module																																																														
G	2015	Express	Body	Instrument Cluster																																																														
G	2015	Express	Body	Digital Radio Receiver Control Module																																																														
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																														
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																														
G	2015	Express	Body	Auxiliary Heater Control Module																																																														
G	2015	Express	Body	Remote Control Door Lock Receiver																																																														
G	2015	Express	Body	Parking Assist Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2015	Express	Body	Theft Deterrent Module																																																														
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																														
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																														
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																														
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																														
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																														
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																													V			
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																														
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																														
G	2015	Savana	Chassis	Electronic Brake Control Module																																																														
G	2015	Savana	Body	Body Control Module																																																													
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
G	2015	Savana	Body	Rollover Sensor Module																																																													
G	2015	Savana	Body	Instrument Cluster																																																													
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																													
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																													
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																													
G	2015	Savana	Body	Auxiliary Heater Control Module																																																													
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																													
G	2015	Savana	Body	Parking Assist Control Module																																																													
G	2015	Savana	Body	Theft Deterrent Module																																																													
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																													
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																													
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																													
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																													
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																													
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																													V			
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																													
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
G	2016	Express	Chassis	Electronic Brake Control Module																																																													
G	2016	Express	Body	Body Control Module																																																												
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2016	Express	Body	Instrument Cluster																																																												
G	2016	Express	Body	Chime Alarm Control Module																																																												
G	2016	Express	Body	Base Radio																																																											
G	2016	Express	Body	Navigation Radio																																																											
G	2016	Express	Body	Uplevel Radio																																																											
G	2016	Express	Body	Digital Radio Receiver Control Module																																																												
G	2016	Express	Body	Telematics Communication Interface Control Module																																																												
G	2016	Express	Body	Auxiliary Heater Control Module																																																												
G	2016	Express	Body	Remote Control Door Lock Receiver																																																												
G	2016	Express	Body	Parking Assist Control Module																																																												
G	2016	Express	Body	Theft Deterrent Module																																																												
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											V			
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																														
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																														
G	2016	Savana	Chassis	Electronic Brake Control Module																																																														
G	2016	Savana	Body	Body Control Module																																																													
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
G	2016	Savana	Body	Instrument Cluster																																																													
G	2016	Savana	Body	Chime Alarm Control Module																																																													
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																													
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																													
G	2016	Savana	Body	Auxiliary Heater Control Module																																																													
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																													
G	2016	Savana	Body	Parking Assist Control Module																																																													
G	2016	Savana	Body	Theft Deterrent Module																																																													
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																													
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																													
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																													
H	2004	Express/Savana	Chassis	VSES																																																													
H	2004	Express/Savana	Body	Body Control Module																																																													
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																													
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																													
H	2004	Express/Savana	Body	OnStar																																																													
H	2004	Express/Savana	Body	Base Radio																																																													
H	2004	Express/Savana	Body	Uplevel Radio																																																													
H	2004	Express/Savana	Body	Remote Function Actuation																																																													
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																													
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																													
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																													
H	2004	Express Access/Savana Pro	Chassis	VSES																																																													
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																													
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																													
H	2004	Express Access/Savana Pro	Body	OnStar																																																													
H	2004	Express Access/Savana Pro	Body	Base Radio																																																													
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																													
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																													
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																													
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																													
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																													
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																													
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																													
H	2005	Express/Savana	Chassis	VSES																																																													
H	2005	Express/Savana	Body	Body Control Module																																																													
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																													
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																													
H	2005	Express/Savana	Body	Base Radio																																																													
H	2005	Express/Savana	Body	Uplevel Radio																																																													
H	2005	Express/Savana	Body	Remote Function Actuation																																																													
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2005	Express Access/Savana Pro	Chassis	VSES																																																												
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2005	Express Access/Savana Pro	Body	Base Radio																																																												
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																												
H	2006	Express/Savana	Chassis	VSES																																																												
H	2006	Express/Savana	Body	Body Control Module																																																												
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																												
H	2006	Express/Savana	Body	Passenger Presence System																																																												
H	2006	Express/Savana	Body	Base Radio																																																												
H	2006	Express/Savana	Body	Uplevel Radio																																																												
H	2006	Express/Savana	Body	Remote Function Actuation																																																												
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2006	Express Access/Savana Pro	Chassis	VSES																																																												
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2006	Express Access/Savana Pro	Body	Base Radio																																																												
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2007	Express/Savana	Body	Body Control Module																																																												
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																												
H	2007	Express/Savana	Body	Passenger Presence System																																																												
H	2007	Express/Savana	Body	Base Radio																																																												
H	2007	Express/Savana	Body	Uplevel Radio																																																												
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2007	Express Access/Savana Pro	Body	Base Radio																																																												
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																									V																			
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																									V																			
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																									V																			
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																									V																			
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2008	Express/Savana	Body	Body Control Module																																																												
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2008	Express/Savana	Body	Passenger Presence System																																																												
H	2008	Express/Savana	Body	Radio																																																												
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2008	Express/Savana	Body	Rollover Sensor																																																												
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2008	Express/Savana	Body	Theft Deterrent Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																									V																			
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																									V																			
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								V																		
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																		
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																		
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																		
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								V																		
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module																																																										
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																																										
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express/Savana	Body	Theft Deterrent Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																		
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																		
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								V																		
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																														
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																														
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																														
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																														
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																														
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																														
H	2010	Express/Savana	Body	Body Control Module																																																														
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																														
H	2010	Express/Savana	Body	Passenger Presence System																																																														
H	2010	Express/Savana	Body	Radio																																																														
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																														
H	2010	Express/Savana	Body	Rollover Sensor																																																														
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																														
H	2010	Express/Savana	Body	Theft Deterrent Module																																																														
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																														
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																														
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																														
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																														
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																														
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																														
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																														
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																														
H	2010	Express Access/Savana Pro	Body	Radio																																																														
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																														
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																														
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																														
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																														
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																														
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																														
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																														
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																														
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																														
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																														
H	2011	Express/Savana	Body	Body Control Module																																																														
H	2011	Express/Savana	Body	Digital Radio Receiver																																																														
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																														
H	2011	Express/Savana	Body	Passenger Presence System																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2011	Express/Savana	Body	Radio																																																												
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2011	Express/Savana	Body	Rollover Sensor																																																												
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2011	Express/Savana	Body	Theft Deterrent Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2011	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2011	Express Access/Savana Pro	Body	Radio																																																												
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2012	Express/Savana	Body	Body Control Module																																																												
H	2012	Express/Savana	Body	Digital Radio Receiver																																																												
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2012	Express/Savana	Body	Passenger Presence System																																																												
H	2012	Express/Savana	Body	Radio																																																												
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2012	Express/Savana	Body	Rollover Sensor																																																												
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2012	Express/Savana	Body	Theft Deterrent Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																																												
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2013	Express Access/Savana Pro	Body	Radio																																																												
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																												
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
H	2014	Express	Chassis	Electronic Brake Control Module																																																												
H	2014	Express	Body	Body Control Module																																																												
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2014	Express	Body	Passenger Presence Module																																																												
H	2014	Express	Body	Rollover Sensor Module																																																												
H	2014	Express	Body	Instrument Cluster																																																												
H	2014	Express	Body	Chime Alarm Control Module																																																												
H	2014	Express	Body	Base Radio																																																												
H	2014	Express	Body	Navigation Radio																																																												
H	2014	Express	Body	Uplevel Radio																																																												
H	2014	Express	Body	Digital Radio Receiver Control Module																																																												
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																												
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																												
H	2014	Express	Body	Auxiliary Heater Control Module																																																												
H	2014	Express	Body	Remote Control Door Lock Receiver																																																												
H	2014	Express	Body	Parking Assist Control Module																																																												
H	2014	Express	Body	Theft Deterrent Module																																																												
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																												
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
H	2014	Savana	Chassis	Electronic Brake Control Module																																																														
H	2014	Savana	Body	Body Control Module																																																													
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
H	2014	Savana	Body	Passenger Presence Module																																																													
H	2014	Savana	Body	Rollover Sensor Module																																																													
H	2014	Savana	Body	Instrument Cluster																																																													
H	2014	Savana	Body	Chime Alarm Control Module																																																													
H	2014	Savana	Body	Base Radio																																																													
H	2014	Savana	Body	Navigation Radio																																																													
H	2014	Savana	Body	Uplevel Radio																																																													
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																													
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																													
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																													
H	2014	Savana	Body	Auxiliary Heater Control Module																																																													
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																													
H	2014	Savana	Body	Parking Assist Control Module																																																													
H	2014	Savana	Body	Theft Deterrent Module																																																													
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																													
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																													
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																													
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																													
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																													
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																												V			
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																													
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
H	2015	Express	Chassis	Electronic Brake Control Module																																																													
H	2015	Express	Body	Body Control Module																																																													
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
H	2015	Express	Body	Rollover Sensor Module																																																													
H	2015	Express	Body	Instrument Cluster																																																													
H	2015	Express	Body	Digital Radio Receiver Control Module																																																													
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																													
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																													
H	2015	Express	Body	Auxiliary Heater Control Module																																																													
H	2015	Express	Body	Remote Control Door Lock Receiver																																																													
H	2015	Express	Body	Parking Assist Control Module																																																													
H	2015	Express	Body	Theft Deterrent Module																																																													
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																													
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																													
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																													
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																													
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																													
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											V			
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																													
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
H	2015	Savana	Chassis	Electronic Brake Control Module																																																													
H	2015	Savana	Body	Body Control Module																																																													
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2015	Savana	Body	Rollover Sensor Module																																																														
H	2015	Savana	Body	Instrument Cluster																																																														
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																														
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																														
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																														
H	2015	Savana	Body	Auxiliary Heater Control Module																																																														
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																														
H	2015	Savana	Body	Parking Assist Control Module																																																														
H	2015	Savana	Body	Theft Deterrent Module																																																														
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																														
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																														
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																														
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																														
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																														
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																									V				
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																														
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																														
H	2016	Express	Chassis	Electronic Brake Control Module																																																														
H	2016	Express	Body	Body Control Module																																																														
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
H	2016	Express	Body	Instrument Cluster																																																														
H	2016	Express	Body	Chime Alarm Control Module																																																														
H	2016	Express	Body	Base Radio																																																														
H	2016	Express	Body	Navigation Radio																																																														
H	2016	Express	Body	Uplevel Radio																																																														
H	2016	Express	Body	Digital Radio Receiver Control Module																																																														
H	2016	Express	Body	Telematics Communication Interface Control Module																																																														
H	2016	Express	Body	Auxiliary Heater Control Module																																																														
H	2016	Express	Body	Remote Control Door Lock Receiver																																																														
H	2016	Express	Body	Parking Assist Control Module																																																														
H	2016	Express	Body	Theft Deterrent Module																																																														
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																														
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																														
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																														
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																														
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																														
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									V				
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																														
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																														
H	2016	Savana	Chassis	Electronic Brake Control Module																																																														
H	2016	Savana	Body	Body Control Module																																																														
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
H	2016	Savana	Body	Instrument Cluster																																																														
H	2016	Savana	Body	Chime Alarm Control Module																																																														
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																														
H	2016	Savana	Body	Telematics Communication Interface Control Module																																																														
H	2016	Savana	Body	Auxiliary Heater Control Module																																																														
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																														
H	2016	Savana	Body	Parking Assist Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2016	Savana	Body	Theft Deterrent Module																																																														
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																														
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																														
J	2004	ALL	Chassis	Electronic Brake Control Module																																																														
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																														
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																														
J	2007	ALL	Chassis	Electronic Brake Control Module																																																														
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																														
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																														
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																														
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																														
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																														
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																														
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																														
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																														
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																														
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																														
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																														
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																														
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																														
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																														
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																														
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																														
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																														
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																														
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																														
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																														
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																														
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																														
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																														
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																																														
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																																														
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																														
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																														
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																														
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																																														
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																														
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																														
J	2013	Tracker	Chassis	Power Steering Control Module																																																														
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																														
J	2013	Tracker	Body	Body Control Module																																																														
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
J	2013	Tracker	Body	Passenger Presence Module																																																														
J	2013	Tracker	Body	Instrument Cluster																																																														
J	2013	Tracker	Body	Radio																																																														
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																																														
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																																														
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																																														
J	2013	Tracker	Body	Front Seat Heating Control Module																																																														
J	2013	Tracker	Body	Parking Assist Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2013	Tracker	Body	Frontview Camera Module																																																													
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																													
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																													
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																													
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																													
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																													
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																													
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																											V																	
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																											V																	
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																											V																	
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																											V																	
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																													
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																													
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																													
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																													
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																											V																	
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																													
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																											V																	
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																													
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																											V																	
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																													
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																											V																	
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																													
J	2013	Trax	Chassis	Electronic Brake Control Module																																																													
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																													
J	2013	Trax	Chassis	Power Steering Control Module																																																													
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2013	Trax	Body	Body Control Module																																																													
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2013	Trax	Body	Passenger Presence Module																																																													
J	2013	Trax	Body	Instrument Cluster																																																													
J	2013	Trax	Body	Radio																																																												
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																													
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																													
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																													
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																													
J	2013	Trax	Body	Front Seat Heating Control Module																																																													
J	2013	Trax	Body	Parking Assist Control Module																																																													
J	2013	Trax	Body	Frontview Camera Module																																																													
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																													
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																													
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																													
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																													
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																													
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																													
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																													
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																													
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																													
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																													
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																													
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																											V																	
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																											V																	
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																											V																	
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																											V																	
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																											V																	
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																											V																	
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																											V																	
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																											V																	
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																												
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																																												
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																												
J	2014	Tracker	Chassis	Power Steering Control Module																																																												
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Tracker	Body	Body Control Module																																																												
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Tracker	Body	Passenger Presence Module																																																												
J	2014	Tracker	Body	Instrument Cluster																																																												
J	2014	Tracker	Body	Radio																																																											
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																																												
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Tracker	Body	Front Seat Heating Control Module																																																												
J	2014	Tracker	Body	Parking Assist Control Module																																																												
J	2014	Tracker	Body	Frontview Camera Module																																																												
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																														
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																												V																	
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																												V																	
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																												V																	
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																												V																	
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																													
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																													
J	2014	Trax	Chassis	Electronic Brake Control Module																																																													
J	2014	Trax	Chassis	Power Steering Control Module																																																													
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2014	Trax	Body	Body Control Module																																																													
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2014	Trax	Body	Passenger Presence Module																																																													
J	2014	Trax	Body	Instrument Cluster																																																													
J	2014	Trax	Body	Radio																																																												
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																													
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																													
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																													
J	2014	Trax	Body	Front Seat Heating Control Module																																																													
J	2014	Trax	Body	Parking Assist Control Module																																																													
J	2014	Trax	Body	Frontview Camera Module																																																													
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																													
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																													
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																													
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																												V																	
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																												V																	
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																												V																	
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																												V																	
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																												
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																												
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																												
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																												
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																												
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																												V																	
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																												V																	

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																												
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																										V																
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																										V																
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																										V																
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																										V																
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																										V																
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																										V																
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2015	Tracker	Chassis	Power Steering Control Module																																																										
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Tracker	Body	Body Control Module																																																										
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Tracker	Body	Instrument Cluster																																																										
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																																										
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Tracker	Body	Front Seat Heating Control Module																																																										
J	2015	Tracker	Body	Parking Assist Control Module																																																										
J	2015	Tracker	Body	Frontview Camera Module																																																										
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																										V																
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																										V																
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2015	Trax	Powertrain	Chassis Control Module																																																										
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Trax	Chassis	Electronic Brake Control Module																																																										
J	2015	Trax	Chassis	Power Steering Control Module																																																										
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Trax	Body	Body Control Module																																																										
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Trax	Body	Passenger Presence Module																																																										
J	2015	Trax	Body	Instrument Cluster																																																										
J	2015	Trax	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																														
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																														
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																														
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																														
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																														
J	2015	Trax	Body	Seat Memory Control Module																																																														
J	2015	Trax	Body	Front Seat Heating Control Module																																																														
J	2015	Trax	Body	Right Side Object Detection Control Module																																																														
J	2015	Trax	Body	Left Side Object Detection Control Module																																																														
J	2015	Trax	Body	Parking Assist Control Module																																																														
J	2015	Trax	Body	Frontview Camera Module																																																														
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																														
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																											V																		
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																											V																		
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																														
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																											V																		
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																														
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																											V																		
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																														
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																											V																		
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																											V																		
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																														
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																														
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																														
J	2016	Tracker	Chassis	Power Steering Control Module																																																														
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																														
J	2016	Tracker	Body	Body Control Module																																																														
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
J	2016	Tracker	Body	Instrument Cluster																																																														
J	2016	Tracker	Body	Trailer Interface Control Module																																																														
J	2016	Tracker	Body	Radio																																																														
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																																														
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																																														
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																																														
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																																														
J	2016	Tracker	Body	Front Seat Heating Control Module																																																														
J	2016	Tracker	Body	Parking Assist Control Module																																																														
J	2016	Tracker	Body	Frontview Camera Module																																																														
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																														
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																														
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																														
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																														
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																														
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																														
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																														
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																														
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																										V															
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																										V															
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																								
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																										V															
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																										V															
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																								
J	2016	Trax	Powertrain	Chassis Control Module																																																								
J	2016	Trax	Chassis	Electronic Brake Control Module																																																								
J	2016	Trax	Chassis	Power Steering Control Module																																																								
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2016	Trax	Body	Body Control Module																																																								
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2016	Trax	Body	Passenger Presence Module																																																								
J	2016	Trax	Body	Instrument Cluster																																																								
J	2016	Trax	Body	Trailer Interface Control Module																																																								
J	2016	Trax	Body	Radio																																																								
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																								
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
J	2016	Trax	Body	Seat Memory Control Module																																																								
J	2016	Trax	Body	Front Seat Heating Control Module																																																								
J	2016	Trax	Body	Right Side Object Detection Control Module																																																								
J	2016	Trax	Body	Left Side Object Detection Control Module																																																								
J	2016	Trax	Body	Parking Assist Control Module																																																								
J	2016	Trax	Body	Frontview Camera Module																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																								

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																															
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																																
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																																
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																															
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																															
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																															
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																															
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																															
K	2004	ALL	Chassis	ESC																																																															
K	2004	ALL	Chassis	Rear Wheel Steering																																																															
K	2004	ALL	Chassis	Tire Pressure Monitor																																																															
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																															
K	2004	ALL	Chassis	VSES																																																															
K	2004	ALL	Body	Amplifier (Bose)																																																															
K	2004	ALL	Body	Body Control Module																																																															
K	2004	ALL	Body	CD Changer																																																															
K	2004	ALL	Body	Chime																																																															
K	2004	ALL	Body	Driver Door Module																																																															
K	2004	ALL	Body	Driver Seat Module																																																															
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																															
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																															
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																															
K	2004	ALL	Body	Instrument Panel Cluster																																																															
K	2004	ALL	Body	OnStar																																																															
K	2004	ALL	Body	Passenger Door Module																																																															
K	2004	ALL	Body	Passenger Presence System																																																															
K	2004	ALL	Body	Radio Base																																																															
K	2004	ALL	Body	Radio Uplevel																																																															
K	2004	ALL	Body	Radio Navigation																																																															
K	2004	ALL	Body	Rear Aux. Climate Module																																																															
K	2004	ALL	Body	Rear HVAC																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2004	ALL	Body	Rear Seat Audio																																																														
K	2004	ALL	Body	Rear Seat Entertainment																																																														
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2004	ALL	Body	Vehicle Theft Deterrent																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																														
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																														
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																														
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																														
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																														
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																														
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																													
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																													
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																													
K	2005	ALL	Chassis	ESC																																																													
K	2005	ALL	Chassis	Rear Wheel Steering																																																													
K	2005	ALL	Chassis	Tire Pressure Monitor																																																													
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																													
K	2005	ALL	Chassis	VSES																																																													
K	2005	ALL	Body	Amplifier (Bose)																																																													
K	2005	ALL	Body	Body Control Module																																																													
K	2005	ALL	Body	CD Changer																																																													
K	2005	ALL	Body	Chime																																																													
K	2005	ALL	Body	Disc Player and Video Display																																																													
K	2005	ALL	Body	Driver Door Module																																																													
K	2005	ALL	Body	Driver Seat Module																																																													
K	2005	ALL	Body	Generator Battery Control Module																																																													
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																													
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																													
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																													
K	2005	ALL	Body	Instrument Panel Cluster																																																													
K	2005	ALL	Body	Passenger Door Module																																																													
K	2005	ALL	Body	Passenger Presence System																																																													
K	2005	ALL	Body	Base Radio																																																													
K	2005	ALL	Body	Uplevel Radio																																																													
K	2005	ALL	Body	Navigation Radio																																																													
K	2005	ALL	Body	Rear Aux. Climate Module																																																													
K	2005	ALL	Body	Rear HVAC																																																													
K	2005	ALL	Body	Rear Seat Audio																																																													
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																													
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																													
K	2005	ALL	Body	Vehicle Theft Deterrent																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																													
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																													
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																													
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																													
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																													
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																													
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																													
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																														
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																														
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																														
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																														
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																														
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																														
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																														
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																														
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																														
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																														
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																														
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																														
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																														
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																														
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																														
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																														
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																														
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																														
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																															
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																															
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																															
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																															
K	2006	ALL	Chassis	ESC																																																															
K	2006	ALL	Chassis	Tire Pressure Monitor																																																															
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																															
K	2006	ALL	Chassis	VSES																																																															
K	2006	ALL	Body	Amplifier (Bose)																																																															
K	2006	ALL	Body	Body Control Module																																																															
K	2006	ALL	Body	CD Changer																																																															
K	2006	ALL	Body	Chime																																																															
K	2006	ALL	Body	Disc Player and Video Display																																																															
K	2006	ALL	Body	Driver Door Module																																																															
K	2006	ALL	Body	Driver Seat Module																																																															
K	2006	ALL	Body	Generator Battery Control Module																																																															
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																															

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																				
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																				
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																				
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																				
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Suburban	Chassis	Electronic Suspension Control																																																												
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																												
K	2007	Suburban	Body	Amplifier (Bose)																																																												
K	2007	Suburban	Body	Assist Step Controller																																																												
K	2007	Suburban	Body	Body Control Module																																																												
K	2007	Suburban	Body	Body Control Module (aux.)																																																												
K	2007	Suburban	Body	Digital Radio Receiver																																																												
K	2007	Suburban	Body	Driver Door Switch																																																												
K	2007	Suburban	Body	HVAC Control Module Auto																																																												
K	2007	Suburban	Body	HVAC Control Module Manual																																																												
K	2007	Suburban	Body	Instrument Panel Cluster																																																												
K	2007	Suburban	Body	Lift Gate Module																																																												
K	2007	Suburban	Body	Memory Seat Module																																																												
K	2007	Suburban	Body	Park Assist Module																																																												
K	2007	Suburban	Body	Passenger Door Switch																																																												
K	2007	Suburban	Body	Passenger Presence System																																																												
K	2007	Suburban	Body	Radio																																																											
K	2007	Suburban	Body	Rear Heated Seat Module																																																												
K	2007	Suburban	Body	Rear HVAC/RSA																																																												
K	2007	Suburban	Body	Rollover Sensor																																																												
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2007	Suburban	Body	Theft Deterrent Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																				
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																				
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																				
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																				
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																													
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																													
K	2007	Tahoe	Body	Amplifier (Bose)																																																													
K	2007	Tahoe	Body	Assist Step Controller																																																													
K	2007	Tahoe	Body	Body Control Module																																																													
K	2007	Tahoe	Body	Body Control Module (aux.)																																																													
K	2007	Tahoe	Body	Digital Radio Receiver																																																													
K	2007	Tahoe	Body	Driver Door Switch																																																													
K	2007	Tahoe	Body	HVAC Control Module Auto																																																													
K	2007	Tahoe	Body	HVAC Control Module Manual																																																													
K	2007	Tahoe	Body	Instrument Panel Cluster																																																													
K	2007	Tahoe	Body	Lift Gate Module																																																													
K	2007	Tahoe	Body	Memory Seat Module																																																													
K	2007	Tahoe	Body	Park Assist Module																																																													
K	2007	Tahoe	Body	Passenger Door Switch																																																													
K	2007	Tahoe	Body	Passenger Presence System																																																													
K	2007	Tahoe	Body	Radio																																																													
K	2007	Tahoe	Body	Rear Heated Seat Module																																																													
K	2007	Tahoe	Body	Rear HVAC/RSA																																																													
K	2007	Tahoe	Body	Rollover Sensor																																																													
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																													
K	2007	Tahoe	Body	Theft Deterrent Module																																																													
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																				
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																				
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																				
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																				
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																													
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
K	2008	Avalanche	Chassis	Electronic Brake Control Module																																																													
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																													
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																													
K	2008	Avalanche	Body	Amplifier (Bose)																																																													
K	2008	Avalanche	Body	Assist Step Controller																																																													
K	2008	Avalanche	Body	Body Control Module																																																													
K	2008	Avalanche	Body	Body Control Module (aux.)																																																													
K	2008	Avalanche	Body	Digital Radio Receiver																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2008	Avalanche	Body	Driver Door Switch																																																														
K	2008	Avalanche	Body	HVAC Control Module Auto																																																														
K	2008	Avalanche	Body	HVAC Control Module Manual																																																														
K	2008	Avalanche	Body	Instrument Panel Cluster																																																														
K	2008	Avalanche	Body	Memory Seat Module																																																														
K	2008	Avalanche	Body	Park Assist Module																																																														
K	2008	Avalanche	Body	Passenger Door Switch																																																														
K	2008	Avalanche	Body	Passenger Presence System																																																														
K	2008	Avalanche	Body	Radio																																																														
K	2008	Avalanche	Body	Rear Heated Seat Module																																																														
K	2008	Avalanche	Body	Rear HVAC/RSA																																																														
K	2008	Avalanche	Body	Rollover Sensor																																																														
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																														
K	2008	Avalanche	Body	Theft Deterrent Module																																																														
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																									V																					
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																									V																					
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																														
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																									V																					
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																														
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																									V																					
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																														
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																									V																					
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																														
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																														
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																														
K	2008	Suburban	Chassis	EBCM Under 8600 GVW																																																														
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																														
K	2008	Suburban	Chassis	Electronic Suspension Control																																																														
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																														
K	2008	Suburban	Body	Amplifier (Bose)																																																														
K	2008	Suburban	Body	Assist Step Controller																																																														
K	2008	Suburban	Body	Body Control Module																																																														
K	2008	Suburban	Body	Body Control Module (aux.)																																																														
K	2008	Suburban	Body	Digital Radio Receiver																																																														
K	2008	Suburban	Body	Driver Door Switch																																																														
K	2008	Suburban	Body	HVAC Control Module Auto																																																														
K	2008	Suburban	Body	HVAC Control Module Manual																																																														
K	2008	Suburban	Body	Instrument Panel Cluster																																																														
K	2008	Suburban	Body	Lift Gate Module																																																														
K	2008	Suburban	Body	Memory Seat Module																																																														
K	2008	Suburban	Body	Park Assist Module																																																														
K	2008	Suburban	Body	Passenger Door Switch																																																														
K	2008	Suburban	Body	Passenger Presence System																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2008	Suburban	Body	Radio																																																														
K	2008	Suburban	Body	Rear Heated Seat Module																																																														
K	2008	Suburban	Body	Rear HVAC/RSA																																																													
K	2008	Suburban	Body	Rollover Sensor																																																													
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																																													
K	2008	Suburban	Body	Theft Deterrent Module																																																													
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																				
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																													
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																				
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																													
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																													
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																				
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																				
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																				
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								V																				
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																													
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																													
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																				
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																													
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																				
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																													
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																				
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																													
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																													
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2008	Silverado	Chassis	Electronic Suspension Control																																																													
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																													
K	2008	Silverado	Body	Amplifier (Bose)																																																													
K	2008	Silverado	Body	Body Control Module																																																													
K	2008	Silverado	Body	Body Control Module (aux.)																																																													
K	2008	Silverado	Body	Digital Radio Receiver																																																													
K	2008	Silverado	Body	Driver Door Switch																																																													
K	2008	Silverado	Body	HVAC Control Module Auto																																																													
K	2008	Silverado	Body	HVAC Control Module Manual																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2008	Silverado	Body	Instrument Panel Cluster																																																														
K	2008	Silverado	Body	Memory Seat Module																																																															
K	2008	Silverado	Body	Park Assist Module																																																															
K	2008	Silverado	Body	Passenger Door Switch																																																															
K	2008	Silverado	Body	Passenger Presence System																																																															
K	2008	Silverado	Body	Radio																																																															
K	2008	Silverado	Body	Rear Heated Seat Module																																																															
K	2008	Silverado	Body	Rear HVAC/RSA																																																															
K	2008	Silverado	Body	Rollover Sensor																																																															
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																																															
K	2008	Silverado	Body	Theft Deterrent Module																																																															
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																						
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																															
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																															
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																						
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																															
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																						
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																															
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																															
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																															
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																															
K	2008	Tahoe	Chassis	Electronic Brake Control Module																																																															
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																															
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																															
K	2008	Tahoe	Body	Amplifier (Bose)																																																															
K	2008	Tahoe	Body	Assist Step Controller																																																															
K	2008	Tahoe	Body	Body Control Module																																																															
K	2008	Tahoe	Body	Body Control Module (aux.)																																																															
K	2008	Tahoe	Body	Digital Radio Receiver																																																															
K	2008	Tahoe	Body	Driver Door Switch																																																															
K	2008	Tahoe	Body	HVAC Control Module Auto																																																															
K	2008	Tahoe	Body	HVAC Control Module Manual																																																															
K	2008	Tahoe	Body	Instrument Panel Cluster																																																															
K	2008	Tahoe	Body	Lift Gate Module																																																															
K	2008	Tahoe	Body	Memory Seat Module																																																															
K	2008	Tahoe	Body	Park Assist Module																																																															
K	2008	Tahoe	Body	Passenger Door Switch																																																															
K	2008	Tahoe	Body	Passenger Presence System																																																															
K	2008	Tahoe	Body	Radio																																																															
K	2008	Tahoe	Body	Rear Heated Seat Module																																																															
K	2008	Tahoe	Body	Rear HVAC/RSA																																																															
K	2008	Tahoe	Body	Rollover Sensor																																																															
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																															
K	2008	Tahoe	Body	Theft Deterrent Module																																																															
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																						
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																															
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																															
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																															
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																													
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																													
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																													
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																													
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																													
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																													
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																													
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																													
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																													
K	2008	Tahoe Hybrid	Body	Body Control Module																																																													
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																													
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																													
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																																													
K	2008	Tahoe Hybrid	Body	HVAC Control Module																																																													
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																													
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																													
K	2008	Tahoe Hybrid	Body	Memory Seat Module																																																													
K	2008	Tahoe Hybrid	Body	Park Assist Module																																																													
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																													
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																																													
K	2008	Tahoe Hybrid	Body	Radio																																																													
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																													
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																													
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																													
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																													
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																													
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																													
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																			
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																													
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																													
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																			
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																													
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																													
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																			
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																													
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																													
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																			
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																													
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
K	2009	Avalanche	Chassis	Electronic Brake Control Module																																																													
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																														
K	2009	Avalanche	Body	Amplifier (Bose)																																																														
K	2009	Avalanche	Body	Assist Step Controller																																																														
K	2009	Avalanche	Body	Body Control Module																																																														
K	2009	Avalanche	Body	Body Control Module (aux.)																																																														
K	2009	Avalanche	Body	Digital Radio Receiver																																																														
K	2009	Avalanche	Body	Driver Door Switch																																																														
K	2009	Avalanche	Body	HVAC Control Module Auto																																																														
K	2009	Avalanche	Body	HVAC Control Module Manual																																																														
K	2009	Avalanche	Body	Instrument Panel Cluster																																																														
K	2009	Avalanche	Body	Memory Seat Module																																																														
K	2009	Avalanche	Body	Park Assist Module																																																														
K	2009	Avalanche	Body	Passenger Door Switch																																																														
K	2009	Avalanche	Body	Passenger Presence System																																																														
K	2009	Avalanche	Body	Radio																																																														
K	2009	Avalanche	Body	Rear Heated Seat Module																																																														
K	2009	Avalanche	Body	Rear HVAC/RSA																																																														
K	2009	Avalanche	Body	Rollover Sensor																																																														
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																														
K	2009	Avalanche	Body	Theft Deterrent Module																																																														
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																									V																					
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																														
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																									V																					
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																														
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																														
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																														
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																														
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																														
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																														
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																														
K	2009	Cheyenne	Body	Amplifier (Bose)																																																														
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																														
K	2009	Cheyenne	Body	Digital Radio Receiver																																																														
K	2009	Cheyenne	Body	Driver Door Switch																																																														
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																														
K	2009	Cheyenne	Body	Park Assist Module																																																														
K	2009	Cheyenne	Body	Passenger Door Switch																																																														
K	2009	Cheyenne	Body	Passenger Presence System																																																														
K	2009	Cheyenne	Body	Rear Heated Seat Module																																																														
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																														
K	2009	Cheyenne	Body	Rollover Sensor																																																														
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																														
K	2009	Cheyenne	Body	Theft Deterrent Module																																																														
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																									V																					
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2009	Silverado	Body	Passenger Presence System																																																															
K	2009	Silverado	Body	Radio																																																															
K	2009	Silverado	Body	Rear Heated Seat Module																																																															
K	2009	Silverado	Body	Rear HVAC/RSA																																																															
K	2009	Silverado	Body	Rollover Sensor																																																															
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																																															
K	2009	Silverado	Body	Theft Deterrent Module																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																						
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																															
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																															
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																															
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																															
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																															
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																															
K	2009	Silverado Hybrid	Body	Body Control Module																																																															
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																															
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																															
K	2009	Silverado Hybrid	Body	Driver Door Switch																																																															
K	2009	Silverado Hybrid	Body	HVAC Control Module																																																															
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																															
K	2009	Silverado Hybrid	Body	Memory Seat Module																																																															
K	2009	Silverado Hybrid	Body	Park Assist Module																																																															
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																																															
K	2009	Silverado Hybrid	Body	Passenger Presence System																																																															
K	2009	Silverado Hybrid	Body	Radio																																																															
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																															
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																															
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																															
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																															
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																															
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																															
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																						
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																															
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																															
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																															
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																						
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																															
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																															
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																															
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																						
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																															

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																																
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																																
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																																																
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																																																
K	2009	Tahoe Hybrid	Body	HVAC Control Module																																																																
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																																
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																																
K	2009	Tahoe Hybrid	Body	Park Assist Module																																																																
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																																
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																																																
K	2009	Tahoe Hybrid	Body	Radio																																																																
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																																
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																																
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																																
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																																
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																																
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																																
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																																
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																																
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																																
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																																
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																																
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																																
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																																
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																																
K	2010	Avalanche	Chassis	Electronic Brake Control Module																																																																
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																																
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																																
K	2010	Avalanche	Body	Amplifier (Bose)																																																																
K	2010	Avalanche	Body	Assist Step Controller																																																																
K	2010	Avalanche	Body	Body Control Module																																																																
K	2010	Avalanche	Body	Body Control Module (aux.)																																																																
K	2010	Avalanche	Body	Digital Radio Receiver																																																																
K	2010	Avalanche	Body	Driver Door Switch																																																																
K	2010	Avalanche	Body	HVAC Control Module Auto																																																																
K	2010	Avalanche	Body	HVAC Control Module Manual																																																																
K	2010	Avalanche	Body	Instrument Panel Cluster																																																																
K	2010	Avalanche	Body	Memory Seat Module																																																																
K	2010	Avalanche	Body	Park Assist Module																																																																
K	2010	Avalanche	Body	Passenger Door Switch																																																																
K	2010	Avalanche	Body	Passenger Presence System																																																																
K	2010	Avalanche	Body	Radio																																																																
K	2010	Avalanche	Body	Rear Heated Seat Module																																																																
K	2010	Avalanche	Body	Rear HVAC/RSA																																																																
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																																
K	2010	Avalanche	Body	Theft Deterrent Module																																																																
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																																
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																																

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																													
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																													
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																													
K	2010	Cheyenne	Body	Amplifier (Bose)																																																													
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																													
K	2010	Cheyenne	Body	Digital Radio Receiver																																																													
K	2010	Cheyenne	Body	Driver Door Switch																																																													
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																													
K	2010	Cheyenne	Body	Park Assist Module																																																													
K	2010	Cheyenne	Body	Passenger Door Switch																																																													
K	2010	Cheyenne	Body	Passenger Presence System																																																													
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																													
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																													
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																													
K	2010	Cheyenne	Body	Theft Deterrent Module																																																													
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																													
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																													
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																													
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																													
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																													
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																													
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																													
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																													
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2010	Suburban	Chassis	Electronic Suspension Control																																																													
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																													
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																													
K	2010	Suburban	Body	Amplifier (Bose)																																																													
K	2010	Suburban	Body	Assist Step Controller																																																													
K	2010	Suburban	Body	Body Control Module																																																													
K	2010	Suburban	Body	Body Control Module (aux.)																																																													
K	2010	Suburban	Body	Digital Radio Receiver																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2010	Suburban	Body	Driver Door Switch																																																													
K	2010	Suburban	Body	HVAC Control Module Auto																																																														
K	2010	Suburban	Body	HVAC Control Module Manual																																																														
K	2010	Suburban	Body	Instrument Panel Cluster																																																														
K	2010	Suburban	Body	Left Side Object Detection Module																																																														
K	2010	Suburban	Body	Lift Gate Module																																																														
K	2010	Suburban	Body	Memory Seat Module																																																														
K	2010	Suburban	Body	Park Assist Module																																																														
K	2010	Suburban	Body	Passenger Door Switch																																																														
K	2010	Suburban	Body	Passenger Presence System																																																														
K	2010	Suburban	Body	Radio																																																														
K	2010	Suburban	Body	Rear Heated Seat Module																																																														
K	2010	Suburban	Body	Rear HVAC/RSA																																																														
K	2010	Suburban	Body	Right Side Object Detection Module																																																														
K	2010	Suburban	Body	Supplemental Inflatable Restraint																																																														
K	2010	Suburban	Body	Theft Deterrent Module																																																														
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																														
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																														
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																														
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																														
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																														
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																														
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																														
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																														
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																														
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																														
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																														
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																		
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																														
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																														
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																														
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																														
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													
K	2010	Silverado	Chassis	Electronic Suspension Control																																																														
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																													
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																													
K	2010	Silverado	Body	Amplifier (Bose)																																																													
K	2010	Silverado	Body	Body Control Module																																																													
K	2010	Silverado	Body	Body Control Module (aux.)																																																													
K	2010	Silverado	Body	Digital Radio Receiver																																																													
K	2010	Silverado	Body	Driver Door Switch																																																													
K	2010	Silverado	Body	HVAC Control Module Auto																																																													
K	2010	Silverado	Body	HVAC Control Module Manual																																																													
K	2010	Silverado	Body	Instrument Panel Cluster																																																													
K	2010	Silverado	Body	Memory Seat Module																																																													
K	2010	Silverado	Body	Park Assist Module																																																													
K	2010	Silverado	Body	Passenger Door Switch																																																													
K	2010	Silverado	Body	Passenger Presence System																																																													
K	2010	Silverado	Body	Radio																																																													
K	2010	Silverado	Body	Rear Heated Seat Module																																																													
K	2010	Silverado	Body	Rear HVAC/RSA																																																													
K	2010	Silverado	Body	Supplemental Inflatable Restraint																																																													
K	2010	Silverado	Body	Theft Deterrent Module																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																			
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																													
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																													
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																													
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																													
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																													
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																													
K	2010	Silverado Hybrid	Body	Body Control Module																																																													
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																													
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																													
K	2010	Silverado Hybrid	Body	Driver Door Switch																																																													
K	2010	Silverado Hybrid	Body	Heated Seat Module																																																													
K	2010	Silverado Hybrid	Body	HVAC Control Module																																																													
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																													
K	2010	Silverado Hybrid	Body	Park Assist Module																																																													
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																																													
K	2010	Silverado Hybrid	Body	Passenger Presence System																																																													
K	2010	Silverado Hybrid	Body	Radio																																																													
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																													
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																													
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																													
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																												
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Tahoe	Body	Amplifier (Bose)																																																												
K	2010	Tahoe	Body	Assist Step Controller																																																												
K	2010	Tahoe	Body	Body Control Module																																																												
K	2010	Tahoe	Body	Body Control Module (aux.)																																																												
K	2010	Tahoe	Body	Digital Radio Receiver																																																												
K	2010	Tahoe	Body	Driver Door Switch																																																												
K	2010	Tahoe	Body	HVAC Control Module Auto																																																												
K	2010	Tahoe	Body	HVAC Control Module Manual																																																												
K	2010	Tahoe	Body	Instrument Panel Cluster																																																												
K	2010	Tahoe	Body	Left Side Object Detection Module																																																												
K	2010	Tahoe	Body	Lift Gate Module																																																												
K	2010	Tahoe	Body	Memory Seat Module																																																												
K	2010	Tahoe	Body	Park Assist Module																																																												
K	2010	Tahoe	Body	Passenger Door Switch																																																												
K	2010	Tahoe	Body	Passenger Presence System																																																												
K	2010	Tahoe	Body	Radio																																																												
K	2010	Tahoe	Body	Rear Heated Seat Module																																																												
K	2010	Tahoe	Body	Rear HVAC/RSA																																																												
K	2010	Tahoe	Body	Right Side Object Detection Module																																																												
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2010	Tahoe	Body	Theft Deterrent Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																				
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Tahoe Hybrid	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																														
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																														
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																																														
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																																														
K	2010	Tahoe Hybrid	Body	HVAC Control Module																																																														
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																														
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																														
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																																														
K	2010	Tahoe Hybrid	Body	Park Assist Module																																																														
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																														
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																																														
K	2010	Tahoe Hybrid	Body	Radio																																																														
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																														
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																														
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																														
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																														
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																														
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																														
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																														
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																														
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module																																																														
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module																																																														
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																														
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																														
K	2011	Avalanche	Chassis	Electronic Brake Control Module																																																														
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																														
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																														
K	2011	Avalanche	Body	Amplifier (Bose)																																																														
K	2011	Avalanche	Body	Assist Step Controller																																																														
K	2011	Avalanche	Body	Body Control Module																																																														
K	2011	Avalanche	Body	Body Control Module (aux.)																																																														
K	2011	Avalanche	Body	Digital Radio Receiver																																																														
K	2011	Avalanche	Body	Driver Door Switch																																																														
K	2011	Avalanche	Body	HVAC Control Module Auto																																																														
K	2011	Avalanche	Body	HVAC Control Module Manual																																																														
K	2011	Avalanche	Body	Instrument Panel Cluster																																																														
K	2011	Avalanche	Body	Memory Seat Module																																																														
K	2011	Avalanche	Body	Park Assist Module																																																														
K	2011	Avalanche	Body	Passenger Door Switch																																																														
K	2011	Avalanche	Body	Passenger Presence System																																																														
K	2011	Avalanche	Body	Radio																																																														
K	2011	Avalanche	Body	Rear Heated Seat Module																																																														
K	2011	Avalanche	Body	Rear HVAC/RSA																																																														
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																														
K	2011	Avalanche	Body	Theft Deterrent Module																																																														
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																													
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																													
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																													
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																													
K	2011	Cheyenne	Body	Amplifier (Bose)																																																													
K	2011	Cheyenne	Body	Body Control Module																																																													
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																													
K	2011	Cheyenne	Body	Digital Radio Receiver																																																													
K	2011	Cheyenne	Body	Driver Door Switch																																																													
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																													
K	2011	Cheyenne	Body	Park Assist Module																																																													
K	2011	Cheyenne	Body	Passenger Door Switch																																																													
K	2011	Cheyenne	Body	Passenger Presence System																																																													
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																													
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																													
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																													
K	2011	Cheyenne	Body	Theft Deterrent Module																																																													
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																													
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																													
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																													
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																													
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																													
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
K	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																													
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2011	Suburban	Chassis	Electronic Suspension Control																																																													
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																													
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																													
K	2011	Suburban	Body	Amplifier (Bose)																																																													
K	2011	Suburban	Body	Assist Step Controller																																																													
K	2011	Suburban	Body	Body Control Module																																																													
K	2011	Suburban	Body	Body Control Module (aux.)																																																													
K	2011	Suburban	Body	Digital Radio Receiver																																																													
K	2011	Suburban	Body	Driver Door Switch																																																													
K	2011	Suburban	Body	HVAC Control Module Auto																																																													
K	2011	Suburban	Body	HVAC Control Module Manual																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2011	Suburban	Body	Instrument Panel Cluster																																																														
K	2011	Suburban	Body	Left Side Object Detection Module																																																														
K	2011	Suburban	Body	Lift Gate Module																																																														
K	2011	Suburban	Body	Memory Seat Module																																																														
K	2011	Suburban	Body	Park Assist Module																																																														
K	2011	Suburban	Body	Passenger Door Switch																																																														
K	2011	Suburban	Body	Passenger Presence System																																																														
K	2011	Suburban	Body	Radio																																																														
K	2011	Suburban	Body	Rear Heated Seat Module																																																														
K	2011	Suburban	Body	Rear HVAC/RSA																																																														
K	2011	Suburban	Body	Right Side Object Detection Module																																																														
K	2011	Suburban	Body	Supplemental Inflatable Restraint																																																														
K	2011	Suburban	Body	Theft Deterrent Module																																																														
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																														
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																														
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																														
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																														
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																														
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module																																																														
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module																																									V																					
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																														
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																														
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																														
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																														
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																														
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																									V																					
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																														
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																														
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																														
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																														
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																									V																					
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																														
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																														
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																														
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																														
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																														
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																														
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													
K	2011	Silverado	Chassis	Electronic Suspension Control																																																														
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
K	2011	Silverado	Body	Amplifier (Bose)																																																														
K	2011	Silverado	Body	Body Control Module																																																														
K	2011	Silverado	Body	Body Control Module (aux.)																																																														
K	2011	Silverado	Body	Digital Radio Receiver																																																														
K	2011	Silverado	Body	Driver Door Switch																																																														
K	2011	Silverado	Body	HVAC Control Module Auto																																																														
K	2011	Silverado	Body	HVAC Control Module Manual																																																														
K	2011	Silverado	Body	Instrument Panel Cluster																																																														
K	2011	Silverado	Body	Memory Seat Module																																																														
K	2011	Silverado	Body	Park Assist Module																																																														
K	2011	Silverado	Body	Passenger Door Switch																																																														
K	2011	Silverado	Body	Passenger Presence System																																																														
K	2011	Silverado	Body	Radio																																																														
K	2011	Silverado	Body	Rear Heated Seat Module																																																														
K	2011	Silverado	Body	Rear HVAC/RSA																																																														
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																																														
K	2011	Silverado	Body	Theft Deterrent Module																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																					
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																														
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																														
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																														
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																														
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																														
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																														
K	2011	Silverado Hybrid	Body	Body Control Module																																																														
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																														
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																														
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																														
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																														
K	2011	Silverado Hybrid	Body	HVAC Control Module																																																														
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																														
K	2011	Silverado Hybrid	Body	Park Assist Module																																																														
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																														
K	2011	Silverado Hybrid	Body	Passenger Presence System																																																														
K	2011	Silverado Hybrid	Body	Radio																																																														
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																														
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																														
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																														
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2011	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Tahoe	Body	Amplifier (Bose)																																																												
K	2011	Tahoe	Body	Assist Step Controller																																																												
K	2011	Tahoe	Body	Body Control Module																																																												
K	2011	Tahoe	Body	Body Control Module (aux.)																																																												
K	2011	Tahoe	Body	Digital Radio Receiver																																																												
K	2011	Tahoe	Body	Driver Door Switch																																																												
K	2011	Tahoe	Body	HVAC Control Module Auto																																																												
K	2011	Tahoe	Body	HVAC Control Module Manual																																																												
K	2011	Tahoe	Body	Instrument Panel Cluster																																																												
K	2011	Tahoe	Body	Left Side Object Detection Module																																																												
K	2011	Tahoe	Body	Lift Gate Module																																																												
K	2011	Tahoe	Body	Memory Seat Module																																																												
K	2011	Tahoe	Body	Park Assist Module																																																												
K	2011	Tahoe	Body	Passenger Door Switch																																																												
K	2011	Tahoe	Body	Passenger Presence System																																																												
K	2011	Tahoe	Body	Radio																																																												
K	2011	Tahoe	Body	Rear Heated Seat Module																																																												
K	2011	Tahoe	Body	Rear HVAC/RSA																																																												
K	2011	Tahoe	Body	Right Side Object Detection Module																																																												
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2011	Tahoe	Body	Theft Deterrent Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																				
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
K	2011	Tahoe Hybrid	Body	Body Control Module																																																												
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																																												
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																																												
K	2011	Tahoe Hybrid	Body	HVAC Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																															
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																															
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																																															
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																															
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																															
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																																															
K	2011	Tahoe Hybrid	Body	Radio																																																															
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																															
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																															
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																															
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																															
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																															
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																															
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																															
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																															
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																															
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																															
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																															
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																															
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																															
K	2012	Avalanche	Chassis	Electronic Brake Control Module																																																															
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																															
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																															
K	2012	Avalanche	Body	Amplifier (Bose)																																																															
K	2012	Avalanche	Body	Assist Step Controller																																																															
K	2012	Avalanche	Body	Body Control Module																																																															
K	2012	Avalanche	Body	Body Control Module (aux.)																																																															
K	2012	Avalanche	Body	Digital Radio Receiver																																																															
K	2012	Avalanche	Body	Driver Door Switch																																																															
K	2012	Avalanche	Body	HVAC Control Module Auto																																																															
K	2012	Avalanche	Body	HVAC Control Module Manual																																																															
K	2012	Avalanche	Body	Instrument Panel Cluster																																																															
K	2012	Avalanche	Body	Memory Seat Module																																																															
K	2012	Avalanche	Body	Navigation Radio																																																															
K	2012	Avalanche	Body	Park Assist Module																																																															
K	2012	Avalanche	Body	Passenger Door Switch																																																															
K	2012	Avalanche	Body	Passenger Presence System																																																															
K	2012	Avalanche	Body	Radio																																																															
K	2012	Avalanche	Body	Rear Heated Seat Module																																																															
K	2012	Avalanche	Body	Rear HVAC/RSA																																																															
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																															
K	2012	Avalanche	Body	Theft Deterrent Module																																																															
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																															
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																															
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																													
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																													
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																													
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																													
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																													
K	2012	Cheyenne	Body	Amplifier (Bose)																																																													
K	2012	Cheyenne	Body	Body Control Module																																																													
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																													
K	2012	Cheyenne	Body	Digital Radio Receiver																																																													
K	2012	Cheyenne	Body	Driver Door Switch																																																													
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																													
K	2012	Cheyenne	Body	Park Assist Module																																																													
K	2012	Cheyenne	Body	Passenger Door Switch																																																													
K	2012	Cheyenne	Body	Passenger Presence System																																																													
K	2012	Cheyenne	Body	Rear Heated Seat Module																																																													
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																													
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																													
K	2012	Cheyenne	Body	Theft Deterrent Module																																																													
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																													
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																													
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																													
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																													
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																													
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																													
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																													
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
K	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																													
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2012	Suburban	Chassis	Electronic Suspension Control																																																													
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																													
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																													
K	2012	Suburban	Body	Amplifier (Bose)																																																													
K	2012	Suburban	Body	Assist Step Controller																																																													
K	2012	Suburban	Body	Body Control Module																																																													
K	2012	Suburban	Body	Body Control Module (aux.)																																																													
K	2012	Suburban	Body	Digital Radio Receiver																																																													
K	2012	Suburban	Body	Driver Door Switch																																																													
K	2012	Suburban	Body	HVAC Control Module Auto																																																													
K	2012	Suburban	Body	HVAC Control Module Manual																																																													
K	2012	Suburban	Body	Instrument Panel Cluster																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2012	Suburban	Body	Left Side Object Detection Module																																																														
K	2012	Suburban	Body	Lift Gate Module																																																															
K	2012	Suburban	Body	Memory Seat Module																																																															
K	2012	Suburban	Body	Navigation Radio																																																															
K	2012	Suburban	Body	Park Assist Module																																																															
K	2012	Suburban	Body	Passenger Door Switch																																																															
K	2012	Suburban	Body	Passenger Presence System																																																															
K	2012	Suburban	Body	Radio																																																															
K	2012	Suburban	Body	Rear Heated Seat Module																																																															
K	2012	Suburban	Body	Rear HVAC/RSA																																																															
K	2012	Suburban	Body	Right Side Object Detection Module																																																															
K	2012	Suburban	Body	Supplemental Inflatable Restraint																																																															
K	2012	Suburban	Body	Theft Deterrent Module																																																															
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																															
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																															
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																															
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																															
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																															
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																															
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																															
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																															
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																															
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																															
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																															
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																															
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																															
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																															
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																															
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																															
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V																					
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																															
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																															
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																															
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																															
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																					
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																															
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																															
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																															
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																															
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																															
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																															
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																															
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2012	Silverado	Chassis	Electronic Suspension Control																																																														
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
K	2012	Silverado	Body	Amplifier (Bose)																																																														
K	2012	Silverado	Body	Body Control Module																																																														
K	2012	Silverado	Body	Body Control Module (aux.)																																																														
K	2012	Silverado	Body	Digital Radio Receiver																																																														
K	2012	Silverado	Body	Driver Door Switch																																																														
K	2012	Silverado	Body	HVAC Control Module Auto																																																														
K	2012	Silverado	Body	HVAC Control Module Manual																																																														
K	2012	Silverado	Body	Instrument Panel Cluster																																																														
K	2012	Silverado	Body	Memory Seat Module																																																														
K	2012	Silverado	Body	Navigation Radio																																																														
K	2012	Silverado	Body	Park Assist Module																																																														
K	2012	Silverado	Body	Passenger Door Switch																																																														
K	2012	Silverado	Body	Passenger Presence System																																																														
K	2012	Silverado	Body	Radio																																																														
K	2012	Silverado	Body	Rear Heated Seat Module																																																														
K	2012	Silverado	Body	Rear HVAC/RSA																																																														
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																																														
K	2012	Silverado	Body	Theft Deterrent Module																																																														
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																					
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																														
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																														
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																														
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																														
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																														
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																														
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																														
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																														
K	2012	Silverado Hybrid	Body	Body Control Module																																																														
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																														
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																														
K	2012	Silverado Hybrid	Body	Driver Door Switch																																																														
K	2012	Silverado Hybrid	Body	Heated Seat Module																																																														
K	2012	Silverado Hybrid	Body	HVAC Control Module																																																														
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																														
K	2012	Silverado Hybrid	Body	Navigation Radio																																																														
K	2012	Silverado Hybrid	Body	Park Assist Module																																																														
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																																														
K	2012	Silverado Hybrid	Body	Passenger Presence System																																																														
K	2012	Silverado Hybrid	Body	Radio																																																														
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																														
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																														
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																														
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																														

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2012	Tahoe Hybrid	Body	HVAC Control Module																																																															
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																															
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																															
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																																															
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																															
K	2012	Tahoe Hybrid	Body	Park Assist Module																																																															
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																															
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																																															
K	2012	Tahoe Hybrid	Body	Radio																																																															
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																															
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																															
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																															
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																															
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																															
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																															
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																															
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																															
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																															
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																															
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																															
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																															
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																															
K	2013	Avalanche	Chassis	Electronic Brake Control Module																																																															
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																															
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																															
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																															
K	2013	Avalanche	Body	Amplifier (Bose)																																																															
K	2013	Avalanche	Body	Assist Step Controller																																																															
K	2013	Avalanche	Body	Body Control Module																																																															
K	2013	Avalanche	Body	Body Control Module (aux.)																																																															
K	2013	Avalanche	Body	Digital Radio Receiver																																																															
K	2013	Avalanche	Body	Driver Door Switch																																																															
K	2013	Avalanche	Body	HVAC Control Module Auto																																																															
K	2013	Avalanche	Body	HVAC Control Module Manual																																																															
K	2013	Avalanche	Body	Instrument Panel Cluster																																																															
K	2013	Avalanche	Body	Memory Seat Module																																																															
K	2013	Avalanche	Body	Navigation Radio																																																															
K	2013	Avalanche	Body	Park Assist Module																																																															
K	2013	Avalanche	Body	Passenger Door Switch																																																															
K	2013	Avalanche	Body	Passenger Presence System																																																															
K	2013	Avalanche	Body	Radio																																																															
K	2013	Avalanche	Body	Rear Heated Seat Module																																																															
K	2013	Avalanche	Body	Rear HVAC/RSA																																																															
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																															
K	2013	Avalanche	Body	Theft Deterrent Module																																																															
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																															
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																															
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																														
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																														
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																														
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																														
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																														
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																														
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																														
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																														
K	2013	Cheyenne	Body	Amplifier (Bose)																																																														
K	2013	Cheyenne	Body	Body Control Module																																																														
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																														
K	2013	Cheyenne	Body	Digital Radio Receiver																																																														
K	2013	Cheyenne	Body	Driver Door Switch																																																														
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																														
K	2013	Cheyenne	Body	Park Assist Module																																																														
K	2013	Cheyenne	Body	Passenger Door Switch																																																														
K	2013	Cheyenne	Body	Passenger Presence System																																																														
K	2013	Cheyenne	Body	Rear Heated Seat Module																																																														
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																														
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																														
K	2013	Cheyenne	Body	Theft Deterrent Module																																																														
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																														
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																														
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																														
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																														
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																														
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																														
K	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																														
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																														
K	2013	Suburban	Chassis	Electronic Suspension Control																																																														
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																														
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																														
K	2013	Suburban	Body	Amplifier (Bose)																																																														
K	2013	Suburban	Body	Assist Step Controller																																																														
K	2013	Suburban	Body	Body Control Module																																																														
K	2013	Suburban	Body	Body Control Module (aux.)																																																														
K	2013	Suburban	Body	Digital Radio Receiver																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2013	Suburban	Body	Driver Door Switch																																																													
K	2013	Suburban	Body	HVAC Control Module Auto																																																													
K	2013	Suburban	Body	HVAC Control Module Manual																																																													
K	2013	Suburban	Body	Instrument Panel Cluster																																																													
K	2013	Suburban	Body	Left Side Object Detection Module																																																													
K	2013	Suburban	Body	Lift Gate Module																																																													
K	2013	Suburban	Body	Memory Seat Module																																																													
K	2013	Suburban	Body	Navigation Radio																																																													
K	2013	Suburban	Body	Park Assist Module																																																													
K	2013	Suburban	Body	Passenger Door Switch																																																													
K	2013	Suburban	Body	Passenger Presence System																																																													
K	2013	Suburban	Body	Radio																																																													
K	2013	Suburban	Body	Rear Heated Seat Module																																																													
K	2013	Suburban	Body	Rear HVAC/RSA																																																													
K	2013	Suburban	Body	Right Side Object Detection Module																																																													
K	2013	Suburban	Body	Supplemental Inflatable Restraint																																																													
K	2013	Suburban	Body	Theft Deterrent Module																																																													
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																													
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																													
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																													
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																													
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																													
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																													
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																													
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																													
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V																		
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																														
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																														
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																														
K	2013	Silverado	Chassis	Electronic Suspension Control																																																														
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
K	2013	Silverado	Body	Amplifier (Bose)																																																														
K	2013	Silverado	Body	Body Control Module																																																														
K	2013	Silverado	Body	Body Control Module (aux.)																																																														
K	2013	Silverado	Body	Digital Radio Receiver																																																														
K	2013	Silverado	Body	Driver Door Switch																																																														
K	2013	Silverado	Body	HVAC Control Module Auto																																																														
K	2013	Silverado	Body	HVAC Control Module Manual																																																														
K	2013	Silverado	Body	Instrument Panel Cluster																																																														
K	2013	Silverado	Body	Memory Seat Module																																																														
K	2013	Silverado	Body	Navigation Radio																																																														
K	2013	Silverado	Body	Park Assist Module																																																														
K	2013	Silverado	Body	Passenger Door Switch																																																														
K	2013	Silverado	Body	Passenger Presence System																																																														
K	2013	Silverado	Body	Radio																																																														
K	2013	Silverado	Body	Rear Heated Seat Module																																																														
K	2013	Silverado	Body	Rear HVAC/RSA																																																														
K	2013	Silverado	Body	Supplemental Inflatable Restraint																																																														
K	2013	Silverado	Body	Theft Deterrent Module																																																														
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																					
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																														
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																														
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																														
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																														
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																														
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																														
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																														
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																														
K	2013	Silverado Hybrid	Body	Body Control Module																																																														
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																														
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																														
K	2013	Silverado Hybrid	Body	Driver Door Switch																																																														
K	2013	Silverado Hybrid	Body	Heated Seat Module																																																														
K	2013	Silverado Hybrid	Body	HVAC Control Module																																																														
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																														
K	2013	Silverado Hybrid	Body	Navigation Radio																																																														
K	2013	Silverado Hybrid	Body	Park Assist Module																																																														
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																																														
K	2013	Silverado Hybrid	Body	Passenger Presence System																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2013	Silverado Hybrid	Body	Radio																																																												
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2013	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Tahoe	Body	Amplifier (Bose)																																																												
K	2013	Tahoe	Body	Assist Step Controller																																																												
K	2013	Tahoe	Body	Body Control Module																																																												
K	2013	Tahoe	Body	Body Control Module (aux.)																																																												
K	2013	Tahoe	Body	Digital Radio Receiver																																																												
K	2013	Tahoe	Body	Driver Door Switch																																																												
K	2013	Tahoe	Body	HVAC Control Module Auto																																																												
K	2013	Tahoe	Body	HVAC Control Module Manual																																																												
K	2013	Tahoe	Body	Instrument Panel Cluster																																																												
K	2013	Tahoe	Body	Left Side Object Detection Module																																																												
K	2013	Tahoe	Body	Lift Gate Module																																																												
K	2013	Tahoe	Body	Memory Seat Module																																																												
K	2013	Tahoe	Body	Navigation Radio																																																												
K	2013	Tahoe	Body	Park Assist Module																																																												
K	2013	Tahoe	Body	Passenger Door Switch																																																												
K	2013	Tahoe	Body	Passenger Presence System																																																												
K	2013	Tahoe	Body	Radio																																																												
K	2013	Tahoe	Body	Rear Heated Seat Module																																																												
K	2013	Tahoe	Body	Rear HVAC/RSA																																																												
K	2013	Tahoe	Body	Right Side Object Detection Module																																																												
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2013	Tahoe	Body	Theft Deterrent Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																				
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																															
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																															
K	2013	Tahoe Hybrid	Body	Body Control Module																																																															
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																															
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																															
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																															
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																															
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																																															
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																															
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																															
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																																															
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																															
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																															
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																															
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																																															
K	2013	Tahoe Hybrid	Body	Radio																																																															
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																															
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																															
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																															
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																															
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																															
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																															
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																															
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																															
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																															
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																															
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																															
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																															
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																															
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																															
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																															
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																															
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																															
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																															
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																															
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																															
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																															
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																															
K	2014	Cheyenne	Chassis	Power Steering Control Module																																																															
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																															
K	2014	Cheyenne	Body	Body Control Module																																																															
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
K	2014	Cheyenne	Body	Passenger Presence Module																																																															
K	2014	Cheyenne	Body	Instrument Cluster																																																															
K	2014	Cheyenne	Body	Radio Control																																																															
K	2014	Cheyenne	Body	HVAC Control																																																															
K	2014	Cheyenne	Body	Radio																																																															
K	2014	Cheyenne	Body	Amplifier																																																															
K	2014	Cheyenne	Body	Media Disc Player																																																															
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																															
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2014	Cheyenne	Body	HVAC Control Module																																																											
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																											
K	2014	Cheyenne	Body	Parking Assist Control Module																																																											
K	2014	Cheyenne	Body	Frontview Camera Module																																																											
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2014	Silverado	Chassis	Electronic Brake Control Module																																																											
K	2014	Silverado	Chassis	Parking Brake Control Module																																																											
K	2014	Silverado	Chassis	Power Steering Control Module																																																											
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2014	Silverado	Body	Body Control Module																																																											
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2014	Silverado	Body	Passenger Presence Module																																																											
K	2014	Silverado	Body	Instrument Cluster																																																											
K	2014	Silverado	Body	Radio Control																																																											
K	2014	Silverado	Body	HVAC Control																																																											
K	2014	Silverado	Body	Radio																																																											
K	2014	Silverado	Body	Amplifier																																																											
K	2014	Silverado	Body	Media Disc Player																																																											
K	2014	Silverado	Body	Human Machine Interface Control Module																																																											
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																											
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
K	2014	Silverado	Body	Parking Assist Control Module																																																											
K	2014	Silverado	Body	Frontview Camera Module																																																											
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																											
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																											
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2014	Silverado HD	Chassis	Suspension Control Module																																																														
K	2014	Silverado HD	Body	Body Control Module																																																														
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
K	2014	Silverado HD	Body	Passenger Presence Module																																																														
K	2014	Silverado HD	Body	Instrument Cluster																																																														
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																														
K	2014	Silverado HD	Body	Base Radio																																																														
K	2014	Silverado HD	Body	Navigation Radio																																																														
K	2014	Silverado HD	Body	Uplevel Radio																																																														
K	2014	Silverado HD	Body	Amplifier																																																														
K	2014	Silverado HD	Body	Rear Audio Control Module																																																														
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																														
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																														
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																														
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																														
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																														
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																														
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																														
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																													
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																													
K	2014	Silverado HD	Body	Seat Memory Control Module																																																														
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																													
K	2014	Silverado HD	Body	Parking Assist Control Module																																																													
K	2014	Silverado HD	Body	Theft Deterrent Module																																																													
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																													
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																													
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																													
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																													
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																													
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																													
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																													
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																													
K	2014	Suburban	Chassis	Parking Brake Control Module																																																													
K	2014	Suburban	Chassis	Suspension Control Module																																																														
K	2014	Suburban	Body	Body Control Module																																																													
K	2014	Suburban	Body	Auxiliary Body Control Module																																																													
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
K	2014	Suburban	Body	Passenger Presence Module																																																													
K	2014	Suburban	Body	Instrument Cluster																																																													
K	2014	Suburban	Body	Base Radio																																																													
K	2014	Suburban	Body	Navigation Radio																																																													
K	2014	Suburban	Body	Uplevel Radio																																																													
K	2014	Suburban	Body	Amplifier																																																													
K	2014	Suburban	Body	Rear Audio Control Module																																																													
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																													
K	2014	Suburban	Body	Personal Audio Link Control Module																																																													
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																												
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																													
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																													
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																													
K	2014	Suburban	Body	Liftgate Control Module																																																													
K	2014	Suburban	Body	Seat Memory Control Module																																																													
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																													
K	2014	Suburban	Body	Assist Step Control Module																																																													
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																													
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																													
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																													
K	2014	Suburban	Body	Parking Assist Control Module																																																													
K	2014	Suburban	Body	Theft Deterrent Module																																																													
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																													
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																													
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																													
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																													
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																													
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																													
K	2014	Tahoe	Chassis	Suspension Control Module																																																													
K	2014	Tahoe	Body	Body Control Module																																																													
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																													
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
K	2014	Tahoe	Body	Passenger Presence Module																																																													
K	2014	Tahoe	Body	Instrument Cluster																																																													
K	2014	Tahoe	Body	Base Radio																																																													
K	2014	Tahoe	Body	Navigation Radio																																																													
K	2014	Tahoe	Body	Uplevel Radio																																																													
K	2014	Tahoe	Body	Amplifier																																																													
K	2014	Tahoe	Body	Rear Audio Control Module																																																													
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																													
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																													
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																													
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																													
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																													
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																													
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																													
K	2014	Tahoe	Body	Liftgate Control Module																																																													
K	2014	Tahoe	Body	Seat Memory Control Module																																																													
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																													
K	2014	Tahoe	Body	Assist Step Control Module																																																													
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																													
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																													
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																													
K	2014	Tahoe	Body	Parking Assist Control Module																																																													
K	2014	Tahoe	Body	Theft Deterrent Module																																																													
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																													
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																												
K	2015	Cheyenne	Chassis	Power Steering Control Module																																																												
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Cheyenne	Chassis	Suspension Control Module																														V	V																													
K	2015	Cheyenne	Body	Body Control Module																																																												
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Cheyenne	Body	Passenger Presence Module																																																												
K	2015	Cheyenne	Body	Instrument Cluster																																																												
K	2015	Cheyenne	Body	Radio Controls																																																												
K	2015	Cheyenne	Body	HVAC Controls																																																												
K	2015	Cheyenne	Body	Radio																																																												
K	2015	Cheyenne	Body	Amplifier																																																												
K	2015	Cheyenne	Body	Media Disc Player																																																												
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																												
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																												
K	2015	Cheyenne	Body	HVAC Control Module																																																												
K	2015	Cheyenne	Body	Parking Assist Control Module																																																												
K	2015	Cheyenne	Body	Frontview Camera Module																																																												
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																												
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2015	Silverado	Chassis	Electronic Brake Control Module																																																												
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																												
K	2015	Silverado	Chassis	Power Steering Control Module																																																												
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Silverado	Chassis	Suspension Control Module																														V	V																													
K	2015	Silverado	Body	Body Control Module																																																												
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Silverado	Body	Passenger Presence Module																																																												
K	2015	Silverado	Body	Instrument Cluster																																																												
K	2015	Silverado	Body	Radio Controls																																																												
K	2015	Silverado	Body	HVAC Controls																																																												
K	2015	Silverado	Body	Radio																																																												
K	2015	Silverado	Body	Amplifier																																																												
K	2015	Silverado	Body	Media Disc Player																																																												
K	2015	Silverado	Body	Human Machine Interface Control Module																																																												
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																																												
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																												
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																												
K	2015	Silverado	Body	Parking Assist Control Module																																																												
K	2015	Silverado	Body	Frontview Camera Module																																																												
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																												
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2015	Suburban	Chassis	Electronic Brake Control Module																																																												
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																												
K	2015	Suburban	Chassis	Parking Brake Control Module																																																												
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2015	Suburban	Chassis	Power Steering Control Module																																																												
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Suburban	Chassis	Suspension Control Module																														V	V																													
K	2015	Suburban	Body	Body Control Module																																																												
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Suburban	Body	Passenger Presence Module																																																												
K	2015	Suburban	Body	Instrument Cluster																																																												
K	2015	Suburban	Body	Radio Controls																																																												
K	2015	Suburban	Body	HVAC Controls																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2015	Suburban	Body	Radio																																																														
K	2015	Suburban	Body	Amplifier																																																														
K	2015	Suburban	Body	Media Disc Player																																																														
K	2015	Suburban	Body	Human Machine Interface Control Module																																																														
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																														
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																														
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																														
K	2015	Suburban	Body	HVAC Control Module																																																														
K	2015	Suburban	Body	Liftgate Control Module																																																														
K	2015	Suburban	Body	Keyless Entry Control Module																																																														
K	2015	Suburban	Body	Assist Step Control Module																																																														
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																														
K	2015	Suburban	Body	Parking Assist Control Module																																																														
K	2015	Suburban	Body	Frontview Camera Module																																																														
K	2015	Suburban	Body	Steering Column Lock Control Module																																																														
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																														
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																														
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																														
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																														
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																														
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																														
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																														
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																														
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																														
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																																														
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																														
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																														
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																														
K	2015	Tahoe	Chassis	Power Steering Control Module																																																														
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																														
K	2015	Tahoe	Chassis	Suspension Control Module																														V	V																															
K	2015	Tahoe	Body	Body Control Module																																																														
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
K	2015	Tahoe	Body	Passenger Presence Module																																																														
K	2015	Tahoe	Body	Instrument Cluster																																																														
K	2015	Tahoe	Body	Radio Controls																																																														
K	2015	Tahoe	Body	HVAC Controls																																																														
K	2015	Tahoe	Body	Radio																																																														
K	2015	Tahoe	Body	Amplifier																																																														
K	2015	Tahoe	Body	Media Disc Player																																																														
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																														
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																														
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																														
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																														
K	2015	Tahoe	Body	HVAC Control Module																																																														
K	2015	Tahoe	Body	Liftgate Control Module																																																														
K	2015	Tahoe	Body	Keyless Entry Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2015	Tahoe	Body	Assist Step Control Module																																																												
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																												
K	2015	Tahoe	Body	Parking Assist Control Module																																																												
K	2015	Tahoe	Body	Frontview Camera Module																																																												
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																												
K	2015	Tahoe	Body	Battery Energy Control Module				V	V	V	V																																																				
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																												
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																												
K	2016	Cheyenne	Chassis	Power Steering Control Module																																																												
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2016	Cheyenne	Chassis	Suspension Control Module																														V	V																													
K	2016	Cheyenne	Body	Body Control Module																																																												
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2016	Cheyenne	Body	Passenger Presence Module																																																												
K	2016	Cheyenne	Body	Instrument Cluster																																																												
K	2016	Cheyenne	Body	Radio Controls																																																												
K	2016	Cheyenne	Body	HVAC Controls																																																												
K	2016	Cheyenne	Body	Radio																																																												
K	2016	Cheyenne	Body	Amplifier																																																												
K	2016	Cheyenne	Body	Media Disc Player																																																												
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																												
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																												
K	2016	Cheyenne	Body	HVAC Control Module																																																												
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																												
K	2016	Cheyenne	Body	Parking Assist Control Module																																																												
K	2016	Cheyenne	Body	Frontview Camera Module																																																												
K	2016	Cheyenne	Body	Frontview Camera Module																																																												
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																												
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																												
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																												
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																												
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																												
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2					V	V		V																																																				
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										V		
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2016	Silverado	Chassis	Electronic Brake Control Module																																																											
K	2016	Silverado	Chassis	Power Steering Control Module																																																											
K	2016	Silverado	Chassis	Power Steering Control Module																																																											
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2016	Silverado	Chassis	Suspension Control Module																														V	V																												
K	2016	Silverado	Body	Body Control Module																																																											
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2016	Silverado	Body	Passenger Presence Module																																																											
K	2016	Silverado	Body	Instrument Cluster																																																											
K	2016	Silverado	Body	Radio Controls																																																										
K	2016	Silverado	Body	HVAC Controls																																																										
K	2016	Silverado	Body	Radio (IO3)																																																										
K	2016	Silverado	Body	Radio (IOB)																																																										
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
K	2016	Silverado	Body	Amplifier																																																										
K	2016	Silverado	Body	Media Disc Player																																																										
K	2016	Silverado	Body	Human Machine Interface Control Module																																																											
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																											
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																											
K	2016	Silverado	Body	Parking Assist Control Module																																																											
K	2016	Silverado	Body	Frontview Camera Module																																																											
K	2016	Silverado	Body	Frontview Camera Module																																																											
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2016	Suburban	Chassis	Electronic Brake Control Module																																																											
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																											
K	2016	Suburban	Chassis	Parking Brake Control Module																																																											
K	2016	Suburban	Chassis	Power Steering Control Module																																																											
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2016	Suburban	Chassis	Suspension Control Module																														V	V																												
K	2016	Suburban	Body	Body Control Module																																																											
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2016	Suburban	Body	Passenger Presence Module																																																												
K	2016	Suburban	Body	Instrument Cluster																																																												
K	2016	Suburban	Body	Radio Controls																																																												
K	2016	Suburban	Body	HVAC Controls																																																												
K	2016	Suburban	Body	Radio																																																												
K	2016	Suburban	Body	Amplifier																																																												
K	2016	Suburban	Body	Media Disc Player																																																												
K	2016	Suburban	Body	Human Machine Interface Control Module																																																												
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																																												
K	2016	Suburban	Body	HVAC Control Module																																																												
K	2016	Suburban	Body	Liftgate Control Module																																																												
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																												
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																												
K	2016	Suburban	Body	Keyless Entry Control Module																																																												
K	2016	Suburban	Body	Assist Step Control Module																																																												
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																												
K	2016	Suburban	Body	Parking Assist Control Module																																																												
K	2016	Suburban	Body	Frontview Camera Module																																																												
K	2016	Suburban	Body	Steering Column Lock Control Module																																																												
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																												
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																												
K	2016	Tahoe	Chassis	Power Steering Control Module																																																												
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2016	Tahoe	Chassis	Suspension Control Module																														V	V																													
K	2016	Tahoe	Body	Body Control Module																																																												
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2016	Tahoe	Body	Passenger Presence Module																																																												
K	2016	Tahoe	Body	Instrument Cluster																																																												
K	2016	Tahoe	Body	Radio Controls																																																												
K	2016	Tahoe	Body	HVAC Controls																																																												
K	2016	Tahoe	Body	Radio																																																												
K	2016	Tahoe	Body	Amplifier																																																												
K	2016	Tahoe	Body	Media Disc Player																																																												
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																												
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																												
K	2016	Tahoe	Body	HVAC Control Module																																																												
K	2016	Tahoe	Body	Liftgate Control Module																																																												
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																												
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																												
K	2016	Tahoe	Body	Keyless Entry Control Module																																																												
K	2016	Tahoe	Body	Assist Step Control Module																																																												
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																												
K	2016	Tahoe	Body	Parking Assist Control Module																																																												
K	2016	Tahoe	Body	Frontview Camera Module																																																												
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																															
L	2004	ALL	Chassis	4WAL 3 Sensor																																																															
L	2004	ALL	Body	Body Control Module																																																															
L	2004	ALL	Body	Instrument Panel Cluster																																																															
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																															
L	2005	Astro	Chassis	4WAL 3 Sensor																																																															
L	2005	Astro	Body	Body Control Module																																																															
L	2005	Astro	Body	Instrument Panel Cluster																																																															
L	2005	Astro	Body	Supplemental Inflatable Restraint																																																															
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																															
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																															
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																																															
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																																															
L	2005	Equinox	Chassis	Electric Power Steering																																																															
L	2005	Equinox	Body	Body Control Module																																																															
L	2005	Equinox	Body	Instrument Panel Cluster																																																															
L	2005	Equinox	Body	Radio																																																															
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																																															
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																													V																	
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																															
L	2006	ALL	Chassis	Traction Control Yes																																																															
L	2006	ALL	Chassis	Traction Control No																																																															
L	2006	ALL	Chassis	Electric Power Steering																																																															
L	2006	ALL	Body	Body Control Module																																																															
L	2006	ALL	Body	Instrument Panel Cluster																																																															
L	2006	ALL	Body	Radio																																																															
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																								V																					
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																															
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																															
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																									V																				
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																																															
L	2007	ALL	Chassis	Power Steering Control Module																																																															
L	2007	ALL	Body	Body Control Module																																																															
L	2007	ALL	Body	Digital Radio Receiver																																																															
L	2007	ALL	Body	Heated Seat Module																																																															
L	2007	ALL	Body	HVAC Control Module																																																															
L	2007	ALL	Body	Instrument Panel Cluster																																																															
L	2007	ALL	Body	Passenger Presence System																																																															
L	2007	ALL	Body	Radio																																																															
L	2007	ALL	Body	Rollover Sensor																																																															
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2007	ALL	Body	Theft Deterrent Module																																																															
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																					V	V																					
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																															
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								V																					
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																									V																			
L	2008	Captiva Sport	Body	Body Control Module																																																												
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																												
L	2008	Captiva Sport	Body	HVAC Control Module Auto																																																												
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																																												
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																																												
L	2008	Captiva Sport	Body	Passenger Presence System																																																												
L	2008	Captiva Sport	Body	Radio																																																												
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2008	Captiva Sport	Body	Rollover Sensor																																																												
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																																												
L	2008	Captiva Sport	Body	Theft Deterrent Module																																																												
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																												
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																												
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																												
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																												
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
L	2008	Equinox	Chassis	Electronic Brake Control Module																																									V																			
L	2008	Equinox	Chassis	Power Steering Control Module																																																												
L	2008	Equinox	Body	Body Control Module																																																												
L	2008	Equinox	Body	Digital Radio Receiver																																																												
L	2008	Equinox	Body	Heated Seat Module																																																												
L	2008	Equinox	Body	HVAC Control Module																																																												
L	2008	Equinox	Body	Instrument Panel Cluster																																																												
L	2008	Equinox	Body	Passenger Presence System																																																												
L	2008	Equinox	Body	Radio																																																												
L	2008	Equinox	Body	Rollover Sensor																																																												
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																																												
L	2008	Equinox	Body	Theft Deterrent Module																																																												
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																												
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																												
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																												
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																												
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								V																			
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																												
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																									V																			
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																												
L	2009	Captiva Sport	Body	Body Control Module																																																												
L	2009	Captiva Sport	Body	HVAC Control Module Auto																																																												
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																																												
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																																												
L	2009	Captiva Sport	Body	Passenger Presence System																																																												
L	2009	Captiva Sport	Body	Radio																																																												
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2009	Captiva Sport	Body	Rollover Sensor																																																												
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																																												
L	2009	Captiva Sport	Body	Theft Deterrent Module																																																												
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																														
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																														
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																														
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																														
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
L	2009	Equinox	Chassis	Electronic Brake Control Module																																									V																			
L	2009	Equinox	Chassis	Power Steering Control Module																																																													
L	2009	Equinox	Body	Body Control Module																																																													
L	2009	Equinox	Body	Digital Radio Receiver																																																													
L	2009	Equinox	Body	Heated Seat Module																																																													
L	2009	Equinox	Body	HVAC Control Module																																																													
L	2009	Equinox	Body	Instrument Panel Cluster																																																													
L	2009	Equinox	Body	Passenger Presence System																																																													
L	2009	Equinox	Body	Radio																																																													
L	2009	Equinox	Body	Rollover Sensor																																																													
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																																													
L	2009	Equinox	Body	Theft Deterrent Module																																																													
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																														
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																														
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																														
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																														
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																														
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																														
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								V																			
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																														
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																														
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																									V																			
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																														
L	2010	Captiva Sport	Body	Body Control Module																																																														
L	2010	Captiva Sport	Body	HVAC Control Module																																																														
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																																														
L	2010	Captiva Sport	Body	Passenger Presence System																																																														
L	2010	Captiva Sport	Body	Radio																																																														
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																																														
L	2010	Captiva Sport	Body	Rollover Sensor																																																														
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																																														
L	2010	Captiva Sport	Body	Theft Deterrent Module																																																														
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																														
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																														
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																														
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																														
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																														
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																														
L	2010	Equinox	Chassis	Electronic Brake Control Module																																																														
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2010	Equinox	Body	Body Control Module																																																														
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2010	Equinox	Body	Passenger Presence Module																																																														
L	2010	Equinox	Body	Instrument Cluster																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2010	Equinox	Body	Radio																																																												
L	2010	Equinox	Body	Multimedia Player Interface Module																																																												
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2010	Equinox	Body	Liftgate Control Module																																																												
L	2010	Equinox	Body	Parking Assist Control Module																																																												
L	2010	Equinox	Body	Frontview Camera Module																																																												
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																																												
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																					V	V	V		V			
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																					V	V	V		V			
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																					V	V	V		V			
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																					V	V	V		V			
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																				V								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																					V							
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
L	2011	Captiva	Chassis	Electronic Brake Control Module																																																												
L	2011	Captiva	Chassis	Parking Brake Control Module																																																												
L	2011	Captiva	Body	Body Control Module																																																												
L	2011	Captiva	Body	Auxiliary Body Control Module																																																												
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2011	Captiva	Body	Instrument Cluster																																																												
L	2011	Captiva	Body	Headlamp Control Module																																																												
L	2011	Captiva	Body	HVAC Control Module																																																												
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																												
L	2011	Captiva	Body	Parking Assist Control Module																																																												
L	2011	Captiva	Body	Theft Deterrent Module																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																												
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																												
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
L	2012	Captiva	Chassis	Electronic Brake Control Module																																																												
L	2012	Captiva	Chassis	Parking Brake Control Module																																																												
L	2012	Captiva	Body	Body Control Module																																																												
L	2012	Captiva	Body	Auxiliary Body Control Module																																																												
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2012	Captiva	Body	Instrument Cluster																																																												
L	2012	Captiva	Body	Headlamp Control Module																																																												
L	2012	Captiva	Body	HVAC Control Module																																																												
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																												
L	2012	Captiva	Body	Parking Assist Control Module																																																												
L	2012	Captiva	Body	Theft Deterrent Module																																																												
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																												
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																												
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																												
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																												
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																												
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																												
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																												
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																												
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module																																										V																		
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																																												
L	2012	Captiva Sport	Body	Body Control Module																																																												
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																												
L	2012	Captiva Sport	Body	HVAC Control Module																																																												
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																																												
L	2012	Captiva Sport	Body	Passenger Presence System																																																												
L	2012	Captiva Sport	Body	Radio																																																												
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2012	Captiva Sport	Body	Rollover Sensor																																																												
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																																																												
L	2012	Captiva Sport	Body	Theft Deterrent Module																																																												
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																												
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2012	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2012	Equinox	Body	Body Control Module																																																												
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2012	Equinox	Body	Passenger Presence Module																																																												
L	2012	Equinox	Body	Instrument Cluster																																																												
L	2012	Equinox	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2012	Equinox	Body	Multimedia Player Interface Module																																																													
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																													
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																													
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																													
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																													
L	2012	Equinox	Body	Liftgate Control Module																																																													
L	2012	Equinox	Body	Parking Assist Control Module																																																													
L	2012	Equinox	Body	Frontview Camera Module																																																													
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																																													
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																	V	V	V		V						
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																	V	V	V		V						
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																													
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																	V	V	V		V						
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																	V	V	V		V						
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																													
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																													
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																													
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																													
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																											V																	
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																											V																	
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																													
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																													
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																													
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																													
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																													
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																													
L	2013	Captiva	Chassis	Parking Brake Control Module																																																													
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																													
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																													
L	2013	Captiva	Body	Auxiliary Body Control Module																																																													
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
L	2013	Captiva	Body	Instrument Cluster																																																													
L	2013	Captiva	Body	Headlamp Control Module																																																													
L	2013	Captiva	Body	HVAC Control Module																																																													
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																													
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																													
L	2013	Captiva	Body	Theft Deterrent Module																																																													
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																													
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																													
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																													
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																													
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																													
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																													
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																									V																	
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																													
L	2013	Captiva Sport	Body	Body Control Module																																																													
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																													
L	2013	Captiva Sport	Body	Heated Seat Module																																																													
L	2013	Captiva Sport	Body	HVAC Control Module																																																													
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2013	Captiva Sport	Body	Park Assist Module																																																														
L	2013	Captiva Sport	Body	Passenger Presence System																																																														
L	2013	Captiva Sport	Body	Radio																																																														
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																														
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																																														
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																														
L	2013	Captiva Sport	Body	Theft Deterrent Module																																																														
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																														
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																														
L	2013	Equinox	Chassis	Electronic Brake Control Module																																																														
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2013	Equinox	Chassis	Power Steering Control Module																																																														
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																														
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																														
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2013	Equinox	Body	Passenger Presence Module																																																														
L	2013	Equinox	Body	Instrument Cluster																																																														
L	2013	Equinox	Body	Radio																																																														
L	2013	Equinox	Body	Rear Audio Control Module																																																														
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																														
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																														
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																														
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																														
L	2013	Equinox	Body	Liftgate Control Module																																																														
L	2013	Equinox	Body	Front Seat Heating Control Module																																																														
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																														
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																														
L	2013	Equinox	Body	Parking Assist Control Module																																																														
L	2013	Equinox	Body	Frontview Camera Module																																																														
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																														
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																														
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																														
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																														
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																														
L	2014	Captiva (3GN)	Body	Body Control Module																																																														
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																														
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																														
L	2014	Captiva (3GN)	Body	Radio																																																														
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																														
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																														
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																														
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																														
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																														
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																														
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																														
L	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																														
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																														V	V	V		V									
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																														V	V	V		V									
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																														
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																														V	V	V		V									
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																														V	V	V		V									
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																														
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																														
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																														
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																														
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission														V																													V																	
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																											V																	
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																														
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																														
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																														
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																														
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																														
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																														
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																														
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																														
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																														
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																														
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2014	Captiva (Other)	Body	Instrument Cluster																																																														
L	2014	Captiva (Other)	Body	Headlamp Control Module																																																														
L	2014	Captiva (Other)	Body	HVAC Control Module																																																														
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																														
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																														
L	2014	Captiva (Other)	Body	Theft Deterrent Module																																																														
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																														
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																														
L	2014	Equinox	Chassis	Electronic Brake Control Module																																																														
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2014	Equinox	Chassis	Power Steering Control Module																																																														
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																														
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																														
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2014	Equinox	Body	Passenger Presence Module																																																														
L	2014	Equinox	Body	Instrument Cluster																																																														
L	2014	Equinox	Body	Radio																																																														
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																														
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																														
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																														
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2014	Equinox	Body	Liftgate Control Module																																																														
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																														
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																														
L	2014	Equinox	Body	Parking Assist Control Module																																																														
L	2014	Equinox	Body	Frontview Camera Module																																																														
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																														
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																														
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																														
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																														
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																														
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																														
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																														
L	2015	Captiva (3GN)	Body	Body Control Module																																																														
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																																														
L	2015	Captiva (3GN)	Body	Instrument Cluster																																																														
L	2015	Captiva (3GN)	Body	Radio																																																														
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																														
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																														
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																														
L	2015	Captiva (3GN)	Body	HVAC Control Module																																																														
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																														
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																														
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																														
L	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																														
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																V	V	V		V									
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																V	V	V		V									
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																														
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																V	V	V		V									
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																V	V	V		V									
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																														
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																														
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																														
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																														
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																														
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																														
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																														
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																														
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																														
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																														
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																														
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																														
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																														
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2015	Captiva (Other)	Body	Instrument Cluster																																																														
L	2015	Captiva (Other)	Body	Headlamp Control Module																																																														
L	2015	Captiva (Other)	Body	HVAC Control Module																																																														
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
L	2015	Captiva (Other)	Body	Theft Deterrent Module																																																												
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2015	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2015	Equinox	Chassis	Power Steering Control Module																																																												
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																																												
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2015	Equinox	Body	Passenger Presence Module																																																												
L	2015	Equinox	Body	Instrument Cluster																																																												
L	2015	Equinox	Body	Radio																																																												
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																																												
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2015	Equinox	Body	Liftgate Control Module																																																												
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																												
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																												
L	2015	Equinox	Body	Parking Assist Control Module																																																												
L	2015	Equinox	Body	Frontview Camera Module																																																												
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																												
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																												
L	2016	Captiva (3GN)	Body	Body Control Module																																																												
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2016	Captiva (3GN)	Body	Instrument Cluster																																																												
L	2016	Captiva (3GN)	Body	Radio																																																												
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																												
L	2016	Captiva (3GN)	Body	HVAC Control Module																																																												
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																												
L	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																												
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																												
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																												
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																												
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																V	V	V		V			
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																V	V	V		V			
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																V	V	V		V			
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																V	V	V		V			
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
M	2004	ALL	Chassis	4WAL 3 Sensor																																																														
M	2004	ALL	Body	Body Control Module																																																														
M	2004	ALL	Body	Instrument Panel Cluster																																																														
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
M	2005	ALL	Chassis	4WAL 3 Sensor																																																														
M	2005	ALL	Body	Body Control Module																																																														
M	2005	ALL	Body	Instrument Panel Cluster																																																														
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																														
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																														
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																														
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																														
P	2007	ALL	Body	Theft Deterrent Module																																																														
R	2009	ALL	Powertrain	Engine Control Module																																																															
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																														
R	2009	ALL	Powertrain	Transmission Control Module																																																															
R	2009	ALL	Chassis	Electronic Brake Control Module																																																															
R	2009	ALL	Body	Body Control Module																																																															
R	2009	ALL	Body	Digital Radio Receiver																																																															
R	2009	ALL	Body	Driver Door Switch																																																															
R	2009	ALL	Body	Heated Seat Module																																																															
R	2009	ALL	Body	HVAC Control Module Auto																																																															
R	2009	ALL	Body	HVAC Control Module Manual																																																															
R	2009	ALL	Body	Instrument Panel Cluster																																																															
R	2009	ALL	Body	Lift Gate Module																																																															
R	2009	ALL	Body	Park Assist Module																																																															
R	2009	ALL	Body	Passenger Door Switch																																																															
R	2009	ALL	Body	Passenger Presence System																																																															
R	2009	ALL	Body	Radio																																																															
R	2009	ALL	Body	Rear HVAC/RSA																																																															
R	2009	ALL	Body	Rollover Sensor																																																															
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
R	2009	ALL	Body	Theft Deterrent Module																																																															
R	2010	ALL	Powertrain	Engine Control Module																																																															
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																															
R	2010	ALL	Powertrain	Transmission Control Module																																																															
R	2010	ALL	Chassis	Electronic Brake Control Module																																																															
R	2010	ALL	Body	Body Control Module																																																															
R	2010	ALL	Body	Digital Radio Receiver																																																															
R	2010	ALL	Body	Driver Door Switch																																																															
R	2010	ALL	Body	Heated Seat Module																																																															
R	2010	ALL	Body	HVAC Control Module Auto																																																															
R	2010	ALL	Body	HVAC Control Module Manual																																																															
R	2010	ALL	Body	Instrument Panel Cluster																																																															
R	2010	ALL	Body	Lift Gate Module																																																															
R	2010	ALL	Body	Park Assist Module																																																															
R	2010	ALL	Body	Passenger Door Switch																																																															
R	2010	ALL	Body	Passenger Presence System																																																															
R	2010	ALL	Body	Radio																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2010	ALL	Body	Rear HVAC/RSA																																																														
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																														
R	2010	ALL	Body	Theft Deterrent Module																																																														
R	2011	ALL	Powertrain	Engine Control Module																																																														
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																														
R	2011	ALL	Powertrain	Transmission Control Module																																																														
R	2011	ALL	Chassis	Electronic Brake Control Module																																																														
R	2011	ALL	Body	Body Control Module																																																														
R	2011	ALL	Body	Digital Radio Receiver																																																														
R	2011	ALL	Body	Driver Door Switch																																																														
R	2011	ALL	Body	Heated Seat Module																																																														
R	2011	ALL	Body	HVAC Control Module Auto																																																														
R	2011	ALL	Body	HVAC Control Module Manual																																																														
R	2011	ALL	Body	Instrument Panel Cluster																																																														
R	2011	ALL	Body	Lift Gate Module																																																														
R	2011	ALL	Body	Park Assist Module																																																														
R	2011	ALL	Body	Passenger Door Switch																																																														
R	2011	ALL	Body	Passenger Presence System																																																														
R	2011	ALL	Body	Radio																																																														
R	2011	ALL	Body	Rear HVAC/RSA																																																														
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																														
R	2011	ALL	Body	Theft Deterrent Module																																																														
R	2012	ALL	Powertrain	Engine Control Module																																																														
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																														
R	2012	ALL	Powertrain	Transmission Control Module																																																														
R	2012	ALL	Chassis	Electronic Brake Control Module																																																														
R	2012	ALL	Body	Body Control Module																																																														
R	2012	ALL	Body	Digital Radio Receiver																																																														
R	2012	ALL	Body	Driver Door Switch																																																														
R	2012	ALL	Body	Heated Seat Module																																																														
R	2012	ALL	Body	HVAC Control Module Auto																																																														
R	2012	ALL	Body	HVAC Control Module Manual																																																														
R	2012	ALL	Body	Instrument Panel Cluster																																																														
R	2012	ALL	Body	Lift Gate Module																																																														
R	2012	ALL	Body	Park Assist Module																																																														
R	2012	ALL	Body	Passenger Door Switch																																																														
R	2012	ALL	Body	Passenger Presence System																																																														
R	2012	ALL	Body	Radio																																																														
R	2012	ALL	Body	Rear HVAC/RSA																																																														
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																														
R	2012	ALL	Body	Theft Deterrent Module																																																														
R	2013	ALL	Powertrain	Engine Control Module																																																														
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																														
R	2013	ALL	Powertrain	Transmission Control Module																																																														
R	2013	ALL	Chassis	Electronic Brake Control Module																																																														
R	2013	ALL	Body	Body Control Module																																																														
R	2013	ALL	Body	Digital Radio Receiver																																																														
R	2013	ALL	Body	Driver Door Switch																																																														
R	2013	ALL	Body	Heated Seat Module																																																														
R	2013	ALL	Body	HVAC Control Module Auto																																																														
R	2013	ALL	Body	HVAC Control Module Manual																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2013	ALL	Body	Instrument Panel Cluster																																																														
R	2013	ALL	Body	Left Side Object Detection Module																																																														
R	2013	ALL	Body	Lift Gate Module																																																														
R	2013	ALL	Body	Park Assist Module																																																														
R	2013	ALL	Body	Passenger Door Switch																																																														
R	2013	ALL	Body	Passenger Presence System																																																														
R	2013	ALL	Body	Radio																																																														
R	2013	ALL	Body	Rear HVAC/RSA																																																														
R	2013	ALL	Body	Right Side Object Detection Module																																																														
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																														
R	2013	ALL	Body	Theft Deterrent Module																																																														
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																														
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																														
R	2014	Traverse	Powertrain	Chassis Control Module																																																														
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																														
R	2014	Traverse	Chassis	Electronic Brake Control Module																																																														
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																														
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																														
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
R	2014	Traverse	Body	Passenger Presence Module																																																														
R	2014	Traverse	Body	Instrument Cluster																																																														
R	2014	Traverse	Body	Radio																																																														
R	2014	Traverse	Body	Rear Audio Control Module																																																														
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																														
R	2014	Traverse	Body	Personal Audio Link Control Module																																																														
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																														
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																														
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																														
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																														
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																														
R	2014	Traverse	Body	Liftgate Control Module																																																														
R	2014	Traverse	Body	Seat Memory Control Module																																																														
R	2014	Traverse	Body	Front Seat Heating Control Module																																																														
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																														
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																														
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																														
R	2014	Traverse	Body	Parking Assist Control Module																																																														
R	2014	Traverse	Body	Frontview Camera Module																																																														
R	2014	Traverse	Body	Theft Deterrent Module																																																														
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																														
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																														
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																														
R	2015	Traverse	Chassis	Electronic Brake Control Module																																																														
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																														
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																													
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
R	2015	Traverse	Body	Passenger Presence Module																																																														
R	2015	Traverse	Body	Instrument Cluster																																																														
R	2015	Traverse	Body	Radio																																																														
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																													
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																													
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																													
R	2015	Traverse	Body	Liftgate Control Module																																																													
R	2015	Traverse	Body	Seat Memory Control Module																																																													
R	2015	Traverse	Body	Front Seat Heating Control Module																																																													
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																													
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																													
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																													
R	2015	Traverse	Body	Parking Assist Control Module																																																													
R	2015	Traverse	Body	Frontview Camera Module																																																													
R	2015	Traverse	Body	Theft Deterrent Module																																																													
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																													
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																													
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																													
R	2016	Traverse	Chassis	Electronic Brake Control Module																																																													
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																													
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																													
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
R	2016	Traverse	Body	Passenger Presence Module																																																													
R	2016	Traverse	Body	Instrument Cluster																																																													
R	2016	Traverse	Body	Radio																																																												
R	2016	Traverse	Body	Rear Audio Control Module																																																												
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																												
R	2016	Traverse	Body	Personal Audio Link Control Module																																																												
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																												
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																												
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																												
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																												
R	2016	Traverse	Body	Liftgate Control Module																																																												
R	2016	Traverse	Body	Seat Memory Control Module																																																												
R	2016	Traverse	Body	Front Seat Heating Control Module																																																												
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																												
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																												
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																												
R	2016	Traverse	Body	Parking Assist Control Module																																																												
R	2016	Traverse	Body	Frontview Camera Module																																																												
R	2016	Traverse	Body	Theft Deterrent Module																																																												
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
S	2004	S10	Chassis	4WAL 3 Sensor																																																												
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																												
S	2004	S10	Body	Body Control Module																																																											
S	2004	S10	Body	Instrument Panel Cluster																																																												
S	2004	S10	Body	Base Radio																																																											
S	2004	S10	Body	Uplevel Radio																																																											
S	2004	S10	Body	Supplemental Inflatable Restraint																																																											
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																														
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																														
S	2004	Colorado	Chassis	ABS Without Traction Control																																																														
S	2004	Colorado	Chassis	ABS With Traction Control																																																														
S	2004	Colorado	Body	Body Control Module																																																														
S	2004	Colorado	Body	Instrument Panel Cluster																																																														
S	2004	Colorado	Body	OnStar																																																														
S	2004	Colorado	Body	Base Radio																																																														
S	2004	Colorado	Body	Uplevel Radio																																																														
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																																														
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																														
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																														
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																														
S	2004	TrailBlazer	Body	Body Control Module																																																														
S	2004	TrailBlazer	Body	Driver Door Module																																																														
S	2004	TrailBlazer	Body	Driver Seat Module																																																														
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																														
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																														
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																																														
S	2004	TrailBlazer	Body	Lift Gate Module																																																														
S	2004	TrailBlazer	Body	OnStar																																																														
S	2004	TrailBlazer	Body	Passenger Door Module																																																														
S	2004	TrailBlazer	Body	Uplevel Radio																																																														
S	2004	TrailBlazer	Body	Navigation Radio																																																														
S	2004	TrailBlazer	Body	Rear Seat Audio																																																														
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																														
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																														
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																														
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																														
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																														
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																														
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																														
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																														
S	2004	TrailBlazer EXT	Body	Body Control Module																																																														
S	2004	TrailBlazer EXT	Body	Driver Door Module																																																														
S	2004	TrailBlazer EXT	Body	Driver Seat Module																																																														
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																														
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																														
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																														
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																														
S	2004	TrailBlazer EXT	Body	OnStar																																																														
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																																														
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																														
S	2004	TrailBlazer EXT	Body	Navigation Radio																																																														
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																														
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																														
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																														
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																														
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																														
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																														
S	2004	Blazer	Body	Body Control Module																																																														
S	2004	Blazer	Body	Heating and Air Conditioning																																																														
S	2004	Blazer	Body	Instrument Panel Cluster																																																														
S	2004	Blazer	Body	Memory Seat Module																																																														
S	2004	Blazer	Body	Base Radio																																																														
S	2004	Blazer	Body	Uplevel Radio																																																														
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																																														
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																														
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																														
S	2004	SSR	Chassis	4WAL 3 Sensor																																																														
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																														
S	2004	SSR	Body	Amplifier (Bose)																																																														
S	2004	SSR	Body	Body Control Module																																																														
S	2004	SSR	Body	Driver Seat Module																																																														
S	2004	SSR	Body	Instrument Panel Cluster																																																														
S	2004	SSR	Body	Uplevel Radio																																																														
S	2004	SSR	Body	Remote Function Actuation																																																														
S	2004	SSR	Body	Roof and Door Module																																																														
S	2004	SSR	Body	Supplemental Inflatable Restraint																																																														
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																														
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																														
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																														
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																														
S	2005	Colorado	Chassis	ABS Without Traction Control																																																														
S	2005	Colorado	Chassis	ABS With Traction Control																																																														
S	2005	Colorado	Body	Body Control Module																																																														
S	2005	Colorado	Body	Instrument Panel Cluster																																																														
S	2005	Colorado	Body	Base Radio																																																														
S	2005	Colorado	Body	Uplevel Radio																																																														
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																																														
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																																														
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																														
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																														
S	2005	TrailBlazer	Body	Body Control Module																																																														
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																														
S	2005	TrailBlazer	Body	Driver Door Module																																																														
S	2005	TrailBlazer	Body	Driver Seat Module																																																														
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																														
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																														
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2005	TrailBlazer	Body	Lift Gate Module																																																														
S	2005	TrailBlazer	Body	Passenger Door Module																																																														
S	2005	TrailBlazer	Body	Passenger Presence System																																																														
S	2005	TrailBlazer	Body	Uplevel Radio																																																														
S	2005	TrailBlazer	Body	Navigation Radio																																																														
S	2005	TrailBlazer	Body	Rear Seat Audio																																																														
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																														
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																														
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																														
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																					V																									
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																														
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																														
S	2005	TrailBlazer EXT	Body	Body Control Module																																																														
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																														
S	2005	TrailBlazer EXT	Body	Driver Door Module																																																														
S	2005	TrailBlazer EXT	Body	Driver Seat Module																																																														
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																														
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																														
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																														
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																														
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																																														
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																														
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																														
S	2005	TrailBlazer EXT	Body	Navigation Radio																																																														
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																														
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																														
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																														
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																														
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																														
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																														
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																														
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																														
S	2005	Blazer	Body	Body Control Module																																																														
S	2005	Blazer	Body	Heating and Air Conditioning																																																														
S	2005	Blazer	Body	Instrument Panel Cluster																																																														
S	2005	Blazer	Body	Memory Seat Module																																																														
S	2005	Blazer	Body	Base Radio																																																														
S	2005	Blazer	Body	Uplevel Radio																																																														
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																																														
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																														
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
S	2005	SSR	Chassis	4WAL 3 Sensor																																																														
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																														
S	2005	SSR	Body	Amplifier (Bose)																																																														
S	2005	SSR	Body	Body Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2005	SSR	Body	Driver Seat Module																																																														
S	2005	SSR	Body	Instrument Panel Cluster																																																														
S	2005	SSR	Body	Uplevel Radio																																																														
S	2005	SSR	Body	Remote Function Actuation																																																														
S	2005	SSR	Body	Roof and Door Module																																																														
S	2005	SSR	Body	Supplemental Inflatable Restraint																																																														
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																														
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																														
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																														
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																														
S	2006	Colorado	Chassis	ABS Without Traction Control																																																														
S	2006	Colorado	Chassis	ABS With Traction Control																																																														
S	2006	Colorado	Body	Body Control Module																																																														
S	2006	Colorado	Body	Instrument Panel Cluster																																																														
S	2006	Colorado	Body	Passenger Presence System																																																														
S	2006	Colorado	Body	Base Radio																																																														
S	2006	Colorado	Body	Uplevel Radio																																																														
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																																														
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																																														
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																						V																								
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																						V																								
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																														
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																														
S	2006	TrailBlazer	Body	Body Control Module																																																														
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																														
S	2006	TrailBlazer	Body	Driver Door Module																																																														
S	2006	TrailBlazer	Body	Driver Seat Module																																																														
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																														
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																														
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																																														
S	2006	TrailBlazer	Body	Lift Gate Module																																																														
S	2006	TrailBlazer	Body	Passenger Door Module																																																														
S	2006	TrailBlazer	Body	Passenger Presence System																																																														
S	2006	TrailBlazer	Body	Uplevel Radio																																																														
S	2006	TrailBlazer	Body	Navigation Radio																																																														
S	2006	TrailBlazer	Body	Rear Seat Audio																																																														
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																														
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																														
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																														
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																						V																								
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																														
S	2006	TrailBlazer EXT	Body	Body Control Module																																																														
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																														
S	2006	TrailBlazer EXT	Body	Driver Door Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2006	TrailBlazer EXT	Body	Driver Seat Module																																																														
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																														
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																														
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																														
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																														
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																																														
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																														
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																														
S	2006	TrailBlazer EXT	Body	Navigation Radio																																																														
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																														
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																														
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																														
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																														
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																														
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																														
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																														
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
S	2006	SSR	Chassis	4WAL 3 Sensor																																																															
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																															
S	2006	SSR	Body	Amplifier (Bose)																																																														
S	2006	SSR	Body	Body Control Module																																																														
S	2006	SSR	Body	Driver Seat Module																																																														
S	2006	SSR	Body	Instrument Panel Cluster																																																														
S	2006	SSR	Body	Uplevel Radio																																																														
S	2006	SSR	Body	Remote Function Actuation																																																														
S	2006	SSR	Body	Roof and Door Module																																																														
S	2006	SSR	Body	Supplemental Inflatable Restraint																																																														
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																V																															
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																V																															
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																														
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																														
S	2007	Colorado	Body	Body Control Module																																																														
S	2007	Colorado	Body	Digital Radio Receiver																																																														
S	2007	Colorado	Body	Generator Battery Control Module																																																														
S	2007	Colorado	Body	Instrument Panel Cluster																																																														
S	2007	Colorado	Body	Passenger Presence System																																																														
S	2007	Colorado	Body	Base Radio																																																														
S	2007	Colorado	Body	Uplevel Radio																																																														
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																																														
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																																														
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																V																															
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																V																															
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																														
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																														
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2007	Trailblazer	Body	Body Control Module																																																												
S	2007	Trailblazer	Body	Digital Radio Receiver																																																												
S	2007	Trailblazer	Body	Disc Player and Video Display																																																												
S	2007	Trailblazer	Body	Driver Door Module																																																												
S	2007	Trailblazer	Body	Driver Seat Module																																																												
S	2007	Trailblazer	Body	Generator Battery Control Module																																																												
S	2007	Trailblazer	Body	HVAC Control Module Auto																																																												
S	2007	Trailblazer	Body	HVAC Control Module Manual																																																												
S	2007	Trailblazer	Body	Instrument Panel Cluster																																																												
S	2007	Trailblazer	Body	Lift Gate Module																																																												
S	2007	Trailblazer	Body	Passenger Door Module																																																												
S	2007	Trailblazer	Body	Passenger Presence System																																																												
S	2007	Trailblazer	Body	Uplevel Radio																																																												
S	2007	Trailblazer	Body	Navigation Radio																																																												
S	2007	Trailblazer	Body	Rear Seat Audio																																																												
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																												
S	2007	Trailblazer	Body	Theft Deterrent Module																																																												
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																												
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2008	Colorado	Body	Body Control Module																																																												
S	2008	Colorado	Body	Digital Radio Receiver																																																												
S	2008	Colorado	Body	Generator Battery Control Module																																																												
S	2008	Colorado	Body	Instrument Panel Cluster																																																												
S	2008	Colorado	Body	Passenger Presence System																																																												
S	2008	Colorado	Body	Base Radio																																																												
S	2008	Colorado	Body	Uplevel Radio																																																												
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2008	Colorado	Body	Theft Deterrent Module																																																												
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																																												
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
S	2008	TrailBlazer	Body	Body Control Module																																																												
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																												
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																												
S	2008	TrailBlazer	Body	Driver Door Module																																																												
S	2008	TrailBlazer	Body	Driver Seat Module																																																												
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																												
S	2008	TrailBlazer	Body	HVAC Control Module Auto																																																												
S	2008	TrailBlazer	Body	HVAC Control Module Manual																																																												
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2008	TrailBlazer	Body	Lift Gate Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2008	TrailBlazer	Body	Passenger Door Module																																																															
S	2008	TrailBlazer	Body	Passenger Presence System																																																															
S	2008	TrailBlazer	Body	Uplevel Radio																																																															
S	2008	TrailBlazer	Body	Navigation Radio																																																															
S	2008	TrailBlazer	Body	Rear Seat Audio																																																															
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																															
S	2008	TrailBlazer	Body	Theft Deterrent Module																																																															
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																															
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																															
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																															
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																															
S	2009	Colorado	Chassis	Electronic Brake Control Module																																																															
S	2009	Colorado	Body	Body Control Module																																																															
S	2009	Colorado	Body	Digital Radio Receiver																																																															
S	2009	Colorado	Body	Generator Battery Control Module																																																															
S	2009	Colorado	Body	Instrument Panel Cluster																																																															
S	2009	Colorado	Body	Passenger Presence System																																																															
S	2009	Colorado	Body	Base Radio																																																															
S	2009	Colorado	Body	Uplevel Radio																																																															
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																																															
S	2009	Colorado	Body	Theft Deterrent Module																																																															
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																															
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																															
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																															
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																															
S	2009	TrailBlazer	Body	Body Control Module																																																															
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																															
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																															
S	2009	TrailBlazer	Body	Driver Door Module																																																															
S	2009	TrailBlazer	Body	Driver Seat Module																																																															
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																															
S	2009	TrailBlazer	Body	HVAC Control Module Auto																																																															
S	2009	TrailBlazer	Body	HVAC Control Module Manual																																																															
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																																															
S	2009	TrailBlazer	Body	Lift Gate Module																																																															
S	2009	TrailBlazer	Body	Passenger Door Module																																																															
S	2009	TrailBlazer	Body	Passenger Presence System																																																															
S	2009	TrailBlazer	Body	Uplevel Radio																																																															
S	2009	TrailBlazer	Body	Navigation Radio																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2009	TrailBlazer	Body	Rear Seat Audio																																																														
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																														
S	2009	TrailBlazer	Body	Theft Deterrent Module																																																														
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																														
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																														
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																														
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																														
S	2010	ALL	Chassis	Electronic Brake Control Module																																																															
S	2010	ALL	Body	Body Control Module																																																															
S	2010	ALL	Body	Digital Radio Receiver																																																															
S	2010	ALL	Body	Generator Battery Control Module																																																															
S	2010	ALL	Body	Instrument Panel Cluster																																																															
S	2010	ALL	Body	Passenger Presence System																																																															
S	2010	ALL	Body	Personal Audio Link Module																																																															
S	2010	ALL	Body	Base Radio																																																															
S	2010	ALL	Body	Uplevel Radio																																																															
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
S	2010	ALL	Body	Theft Deterrent Module																																																															
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																															
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																															
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																															
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																															
S	2011	ALL	Chassis	Electronic Brake Control Module																																																															
S	2011	ALL	Body	Body Control Module																																																															
S	2011	ALL	Body	Digital Radio Receiver																																																															
S	2011	ALL	Body	Generator Battery Control Module																																																															
S	2011	ALL	Body	Instrument Panel Cluster																																																															
S	2011	ALL	Body	Passenger Presence System																																																															
S	2011	ALL	Body	Personal Audio Link Module																																																															
S	2011	ALL	Body	Base Radio																																																															
S	2011	ALL	Body	Uplevel Radio																																																															
S	2011	ALL	Body	Supplemental Inflatable Restraint																																																															
S	2011	ALL	Body	Theft Deterrent Module																																																															
S	2011	ALL	Body	Vehicle Comm. Interface Module																																																															
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																												
S	2012	Colorado (First Gen)	Body	Body Control Module																																																												
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																												
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																												
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																												
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																												
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																												
S	2012	Colorado (First Gen)	Body	Base Radio																																																												
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																												
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																												
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																												
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																												
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																												
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																												
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																												
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																												
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																												
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2012	Colorado (Second Gen)	Body	Body Control Module																																																												
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																												
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																												
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																												
S	2012	S10	Powertrain	Transfer Case Control Module																																																												
S	2012	S10	Chassis	Electronic Brake Control Module																																																												
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2012	S10	Body	Body Control Module																																																												
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2012	S10	Body	Instrument Cluster																																																												
S	2012	S10	Body	Trailer Interface Control Module																																																												
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2013	Trailblazer	Body	Parking Assist Control Module																																																													
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																														
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																														
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																														
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																														
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																														
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																														
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																														
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																														
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2014	Colorado	Body	Body Control Module																																																														
S	2014	Colorado	Body	Body Control Module																																																														
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2014	Colorado	Body	Instrument Cluster																																																														
S	2014	Colorado	Body	Radio																																																														
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																														
S	2014	Colorado	Body	Parking Assist Control Module																																																														
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																														
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																														
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																														
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																														
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																														
S	2014	S10	Powertrain	Transfer Case Control Module																																																														
S	2014	S10	Chassis	Electronic Brake Control Module																																																														
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2014	S10	Body	Body Control Module																																																														
S	2014	S10	Body	Body Control Module																																																														
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2014	S10	Body	Instrument Cluster																																																														
S	2014	S10	Body	Trailer Interface Control Module																																																														
S	2014	S10	Body	Radio																																																														
S	2014	S10	Body	Parking Assist Control Module																																																														
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																														
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																														
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																														
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																														
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																														
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2014	Trailblazer	Body	Body Control Module																																																														
S	2014	Trailblazer	Body	Body Control Module																																																														
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2014	Trailblazer	Body	Instrument Cluster																																																														
S	2014	Trailblazer	Body	Trailer Interface Control Module																																																														
S	2014	Trailblazer	Body	Parking Assist Control Module																																																														
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																														
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																														
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																														
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																														
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																														
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
S	2015	Colorado	Powertrain	Chassis Control Module																																																														
S	2015	Colorado	Powertrain	Transfer Case Control Module																																																														
S	2015	Colorado	Chassis	Electronic Brake Control Module																																																														
S	2015	Colorado	Chassis	Power Steering Control Module																																																														
S	2015	Colorado	Body	Body Control Module																																																														
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2015	Colorado	Body	Passenger Presence Module																																																														
S	2015	Colorado	Body	Radio																																																														
S	2015	Colorado	Body	Amplifier																																																														
S	2015	Colorado	Body	Human Machine Interface Control Module																																																														
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																																														
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																														
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																														
S	2015	Colorado	Body	Frontview Camera Module																																																														
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																														
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																														
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																														
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																														
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2015	Colorado (MMM)	Body	Body Control Module																																																														
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2015	Colorado (MMM)	Body	Instrument Cluster																																																														
S	2015	Colorado (MMM)	Body	Radio																																																															
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																															
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																															
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																												V																		
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																												V																		
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																														
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																														
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																															
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																															
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																															
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																															
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																															
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																															
S	2015	S10	Powertrain	Transfer Case Control Module																																																															
S	2015	S10	Chassis	Electronic Brake Control Module																																																															
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																															
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																															
S	2015	S10	Body	Body Control Module																																																															
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
S	2015	S10	Body	Instrument Cluster																																																															
S	2015	S10	Body	Trailer Interface Control Module																																																															
S	2015	S10	Body	Radio																																																															
S	2015	S10	Body	Telematics Communication Interface Control Module																																																															
S	2015	S10	Body	Parking Assist Control Module																																																															
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																															
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																															
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																															
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																															
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																															
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																															
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																															
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																															
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																															
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																															
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																															
S	2015	Trailblazer	Body	Body Control Module																																																															
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
S	2015	Trailblazer	Body	Instrument Cluster																																																															
S	2015	Trailblazer	Body	Trailer Interface Control Module																																																															
S	2015	Trailblazer	Body	Radio																																																															
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																															
S	2015	Trailblazer	Body	Parking Assist Control Module																																																															
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																															
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																															
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																															
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																															
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																															
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																															
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2016	S10	Body	Instrument Cluster																																																															
S	2016	S10	Body	Trailer Interface Control Module																																																															
S	2016	S10	Body	Radio																																																															
S	2016	S10	Body	Telematics Communication Interface Control Module																																																															
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																															
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																															
S	2016	S10	Body	Parking Assist Control Module																																																															
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																															
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																															
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																															
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																															
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																															
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																															
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																															
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																															
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																															
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																															
S	2016	Trailblazer	Body	Body Control Module																																																															
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
S	2016	Trailblazer	Body	Instrument Cluster																																																															
S	2016	Trailblazer	Body	Trailer Interface Control Module																																																															
S	2016	Trailblazer	Body	Radio																																																															
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																															
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																															
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																															
S	2016	Trailblazer	Body	Parking Assist Control Module																																																															
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																															
T	2004	S10	Chassis	4WAL 3 Sensor																																																															
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																															
T	2004	S10	Body	Body Control Module																																																															
T	2004	S10	Body	Instrument Panel Cluster																																																															
T	2004	S10	Body	Base Radio																																																															
T	2004	S10	Body	Uplevel Radio																																																															
T	2004	S10	Body	Supplemental Inflatable Restraint																																																															
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																															
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																															
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																															
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																															
T	2004	Colorado	Chassis	ABS Without Traction Control																																																															
T	2004	Colorado	Chassis	ABS With Traction Control																																																															
T	2004	Colorado	Body	Body Control Module																																																															
T	2004	Colorado	Body	Instrument Panel Cluster																																																															
T	2004	Colorado	Body	OnStar																																																															
T	2004	Colorado	Body	Base Radio																																																															
T	2004	Colorado	Body	Uplevel Radio																																																															
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																																															
T	2004	Colorado	Body	Instrument Panel Cluster																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																													
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																													
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																													
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																													
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																													
T	2004	TrailBlazer	Body	Body Control Module																																																													
T	2004	TrailBlazer	Body	Driver Door Module																																																													
T	2004	TrailBlazer	Body	Driver Seat Module																																																													
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																													
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																													
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																																													
T	2004	TrailBlazer	Body	Lift Gate Module																																																													
T	2004	TrailBlazer	Body	OnStar																																																													
T	2004	TrailBlazer	Body	Passenger Door Module																																																													
T	2004	TrailBlazer	Body	Uplevel Radio																																																													
T	2004	TrailBlazer	Body	Navigation Radio																																																													
T	2004	TrailBlazer	Body	Rear Seat Audio																																																													
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																													
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																													
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																													
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																													
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																													
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																													
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																													
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																													
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																													
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																													
T	2004	TrailBlazer EXT	Body	Body Control Module																																																													
T	2004	TrailBlazer EXT	Body	Driver Door Module																																																													
T	2004	TrailBlazer EXT	Body	Driver Seat Module																																																													
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																													
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																													
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																													
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																													
T	2004	TrailBlazer EXT	Body	OnStar																																																													
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																																													
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																													
T	2004	TrailBlazer EXT	Body	Navigation Radio																																																													
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																													
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																													
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																													
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																													
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																													
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																													
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																														
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																													
T	2004	Blazer	Body	Body Control Module																																																													
T	2004	Blazer	Body	Heating and Air Conditioning																																																													
T	2004	Blazer	Body	Instrument Panel Cluster																																																													
T	2004	Blazer	Body	Memory Seat Module																																																													
T	2004	Blazer	Body	Base Radio																																																													
T	2004	Blazer	Body	Uplevel Radio																																																													
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																																													
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																													
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																													
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																													
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																													
T	2005	Colorado	Chassis	ABS Without Traction Control																																																													
T	2005	Colorado	Chassis	ABS With Traction Control																																																													
T	2005	Colorado	Body	Body Control Module																																																													
T	2005	Colorado	Body	Instrument Panel Cluster																																																													
T	2005	Colorado	Body	Base Radio																																																													
T	2005	Colorado	Body	Uplevel Radio																																																													
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																																													
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																																													
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																													
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																													
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																													
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																													
T	2005	TrailBlazer	Body	Body Control Module																																																													
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																													
T	2005	TrailBlazer	Body	Driver Door Module																																																													
T	2005	TrailBlazer	Body	Driver Seat Module																																																													
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																													
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																													
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																																													
T	2005	TrailBlazer	Body	Lift Gate Module																																																													
T	2005	TrailBlazer	Body	Passenger Door Module																																																													
T	2005	TrailBlazer	Body	Passenger Presence System																																																													
T	2005	TrailBlazer	Body	Uplevel Radio																																																													
T	2005	TrailBlazer	Body	Navigation Radio																																																													
T	2005	TrailBlazer	Body	Rear Seat Audio																																																													
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																													
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																													
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																													
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																													
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																					V																							
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																															
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																															
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																															
T	2005	TrailBlazer EXT	Body	Body Control Module																																																															
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																															
T	2005	TrailBlazer EXT	Body	Driver Door Module																																																															
T	2005	TrailBlazer EXT	Body	Driver Seat Module																																																															
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																															
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																															
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																															
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																															
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																																															
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																															
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																															
T	2005	TrailBlazer EXT	Body	Navigation Radio																																																															
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																															
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																															
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																															
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																															
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																															
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																															
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																															
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																															
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																															
T	2005	Blazer	Body	Body Control Module																																																															
T	2005	Blazer	Body	Heating and Air Conditioning																																																															
T	2005	Blazer	Body	Instrument Panel Cluster																																																															
T	2005	Blazer	Body	Memory Seat Module																																																															
T	2005	Blazer	Body	Base Radio																																																															
T	2005	Blazer	Body	Uplevel Radio																																																															
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																																															
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																															
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																															
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																															
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																															
T	2006	Colorado	Chassis	ABS Without Traction Control																																																															
T	2006	Colorado	Chassis	ABS With Traction Control																																																															
T	2006	Colorado	Body	Body Control Module																																																															
T	2006	Colorado	Body	Instrument Panel Cluster																																																															
T	2006	Colorado	Body	Passenger Presence System																																																															
T	2006	Colorado	Body	Base Radio																																																															
T	2006	Colorado	Body	Uplevel Radio																																																															
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																																															
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																																															
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																															
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																						V																						
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																											
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																						V																					
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																											
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																											
T	2006	TrailBlazer	Body	Body Control Module																																																											
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																											
T	2006	TrailBlazer	Body	Driver Door Module																																																											
T	2006	TrailBlazer	Body	Driver Seat Module																																																											
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																											
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																											
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																																											
T	2006	TrailBlazer	Body	Lift Gate Module																																																											
T	2006	TrailBlazer	Body	Passenger Door Module																																																											
T	2006	TrailBlazer	Body	Passenger Presence System																																																											
T	2006	TrailBlazer	Body	Uplevel Radio																																																											
T	2006	TrailBlazer	Body	Navigation Radio																																																											
T	2006	TrailBlazer	Body	Rear Seat Audio																																																											
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																											
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																											
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																											
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																						V																					
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																											
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																											
T	2006	TrailBlazer EXT	Body	Body Control Module																																																											
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																											
T	2006	TrailBlazer EXT	Body	Driver Door Module																																																											
T	2006	TrailBlazer EXT	Body	Driver Seat Module																																																											
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																											
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																											
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																											
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																											
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																																											
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																											
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																											
T	2006	TrailBlazer EXT	Body	Navigation Radio																																																											
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																											
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																											
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																											
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																											
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																											
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																											
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																V																												
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																V																												
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																													
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																													
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																													
T	2007	Colorado	Body	Body Control Module																																																													
T	2007	Colorado	Body	Digital Radio Receiver																																																													
T	2007	Colorado	Body	Generator Battery Control Module																																																													
T	2007	Colorado	Body	Instrument Panel Cluster																																																													
T	2007	Colorado	Body	Passenger Presence System																																																													
T	2007	Colorado	Body	Base Radio																																																													
T	2007	Colorado	Body	Uplevel Radio																																																													
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																																													
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																																													
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																V																														
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																													
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																V																														
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																													
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																													
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																													
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																													
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																													
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																													
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																													
T	2007	Trailblazer	Body	Body Control Module																																																													
T	2007	Trailblazer	Body	Digital Radio Receiver																																																													
T	2007	Trailblazer	Body	Disc Player and Video Display																																																													
T	2007	Trailblazer	Body	Driver Door Module																																																													
T	2007	Trailblazer	Body	Driver Seat Module																																																													
T	2007	Trailblazer	Body	Generator Battery Control Module																																																													
T	2007	Trailblazer	Body	HVAC Control Module Auto																																																													
T	2007	Trailblazer	Body	HVAC Control Module Manual																																																													
T	2007	Trailblazer	Body	Instrument Panel Cluster																																																													
T	2007	Trailblazer	Body	Lift Gate Module																																																													
T	2007	Trailblazer	Body	Passenger Door Module																																																													
T	2007	Trailblazer	Body	Passenger Presence System																																																													
T	2007	Trailblazer	Body	Uplevel Radio																																																													
T	2007	Trailblazer	Body	Navigation Radio																																																													
T	2007	Trailblazer	Body	Rear Seat Audio																																																													
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																													
T	2007	Trailblazer	Body	Theft Deterrent Module																																																													
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																													
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																													
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																													
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																													
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																													
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																													
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																													
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																													
T	2008	Colorado	Body	Body Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2008	Colorado	Body	Digital Radio Receiver																																																														
T	2008	Colorado	Body	Generator Battery Control Module																																																														
T	2008	Colorado	Body	Instrument Panel Cluster																																																														
T	2008	Colorado	Body	Passenger Presence System																																																														
T	2008	Colorado	Body	Base Radio																																																														
T	2008	Colorado	Body	Uplevel Radio																																																														
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																																														
T	2008	Colorado	Body	Theft Deterrent Module																																																														
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																																														
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																														
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																														
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																														
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																														
T	2008	TrailBlazer	Body	Body Control Module																																																														
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																														
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																														
T	2008	TrailBlazer	Body	Driver Door Module																																																														
T	2008	TrailBlazer	Body	Driver Seat Module																																																														
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																														
T	2008	TrailBlazer	Body	HVAC Control Module Auto																																																														
T	2008	TrailBlazer	Body	HVAC Control Module Manual																																																														
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																																														
T	2008	TrailBlazer	Body	Lift Gate Module																																																														
T	2008	TrailBlazer	Body	Passenger Door Module																																																														
T	2008	TrailBlazer	Body	Passenger Presence System																																																														
T	2008	TrailBlazer	Body	Uplevel Radio																																																														
T	2008	TrailBlazer	Body	Navigation Radio																																																														
T	2008	TrailBlazer	Body	Rear Seat Audio																																																														
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																														
T	2008	TrailBlazer	Body	Theft Deterrent Module																																																														
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																														
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																														
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																														
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																														
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																														
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																														
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																														
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																														
T	2009	Colorado	Chassis	Electronic Brake Control Module																																																														
T	2009	Colorado	Body	Body Control Module																																																														
T	2009	Colorado	Body	Digital Radio Receiver																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2009	Colorado	Body	Generator Battery Control Module																																																															
T	2009	Colorado	Body	Instrument Panel Cluster																																																															
T	2009	Colorado	Body	Passenger Presence System																																																															
T	2009	Colorado	Body	Base Radio																																																															
T	2009	Colorado	Body	Uplevel Radio																																																															
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																																															
T	2009	Colorado	Body	Theft Deterrent Module																																																															
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																															
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																															
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																															
T	2009	TrailBlazer	Body	Body Control Module																																																															
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																															
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																															
T	2009	TrailBlazer	Body	Driver Door Module																																																															
T	2009	TrailBlazer	Body	Driver Seat Module																																																															
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																															
T	2009	TrailBlazer	Body	HVAC Control Module Auto																																																															
T	2009	TrailBlazer	Body	HVAC Control Module Manual																																																															
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																																															
T	2009	TrailBlazer	Body	Lift Gate Module																																																															
T	2009	TrailBlazer	Body	Passenger Door Module																																																															
T	2009	TrailBlazer	Body	Passenger Presence System																																																															
T	2009	TrailBlazer	Body	Uplevel Radio																																																															
T	2009	TrailBlazer	Body	Navigation Radio																																																															
T	2009	TrailBlazer	Body	Rear Seat Audio																																																															
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																															
T	2009	TrailBlazer	Body	Theft Deterrent Module																																																															
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																															
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																															
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																															
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																															
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																															
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																															
T	2010	ALL	Chassis	Electronic Brake Control Module																																																															
T	2010	ALL	Body	Body Control Module																																																															
T	2010	ALL	Body	Digital Radio Receiver																																																															
T	2010	ALL	Body	Generator Battery Control Module																																																															
T	2010	ALL	Body	Instrument Panel Cluster																																																															
T	2010	ALL	Body	Passenger Presence System																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2010	ALL	Body	Personal Audio Link Module																																																															
T	2010	ALL	Body	Base Radio																																																															
T	2010	ALL	Body	Uplevel Radio																																																															
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
T	2010	ALL	Body	Theft Deterrent Module																																																															
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																															
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																															
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																															
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																															
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																															
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																															
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																															
T	2011	ALL	Chassis	Electronic Brake Control Module																																																															
T	2011	ALL	Body	Body Control Module																																																															
T	2011	ALL	Body	Digital Radio Receiver																																																															
T	2011	ALL	Body	Generator Battery Control Module																																																															
T	2011	ALL	Body	Instrument Panel Cluster																																																															
T	2011	ALL	Body	Passenger Presence System																																																															
T	2011	ALL	Body	Personal Audio Link Module																																																															
T	2011	ALL	Body	Base Radio																																																															
T	2011	ALL	Body	Uplevel Radio																																																															
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																															
T	2011	ALL	Body	Theft Deterrent Module																																																															
T	2011	ALL	Body	Vehicle Comm. Interface Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																															
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																															
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																															
T	2012	Colorado (First Gen)	Body	Body Control Module																																																															
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																															
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																															
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																															
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																															
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																															
T	2012	Colorado (First Gen)	Body	Base Radio																																																															
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																													
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																													
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																													
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																												
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																												
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																												
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																												
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																												
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2012	Colorado (Second Gen)	Body	Body Control Module																																																													
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																												
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																												
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																												V															
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																												V															
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																												
T	2012	S10	Powertrain	Transfer Case Control Module																																																												
T	2012	S10	Chassis	Electronic Brake Control Module																																																												
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2012	S10	Body	Body Control Module																																																												
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2012	S10	Body	Instrument Cluster																																																												
T	2012	S10	Body	Trailer Interface Control Module																																																												
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																												
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																												
T	2013	Colorado	Powertrain	Transfer Case Control Module																																																												
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																												
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																													
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2014	Colorado	Body	Body Control Module																																																													
T	2014	Colorado	Body	Body Control Module																																																													
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2014	Colorado	Body	Instrument Cluster																																																													
T	2014	Colorado	Body	Radio																																																													
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																													
T	2014	Colorado	Body	Parking Assist Control Module																																																													
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																													
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																													
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																													
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																													
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																													
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																													
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																													
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																													
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																													
T	2014	S10	Powertrain	Transfer Case Control Module																																																													
T	2014	S10	Chassis	Electronic Brake Control Module																																																													
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2014	S10	Body	Body Control Module																																																													
T	2014	S10	Body	Body Control Module																																																													
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2014	S10	Body	Instrument Cluster																																																													
T	2014	S10	Body	Trailer Interface Control Module																																																													
T	2014	S10	Body	Radio																																																													
T	2014	S10	Body	Parking Assist Control Module																																																													
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																													
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																													
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																													
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																													
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																													
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																													
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																													
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																													
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																													
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																													
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2014	Trailblazer	Body	Body Control Module																																																													
T	2014	Trailblazer	Body	Body Control Module																																																													
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2014	Trailblazer	Body	Instrument Cluster																																																													
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																													
T	2014	Trailblazer	Body	Parking Assist Control Module																																																													
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																												
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2015	Colorado	Powertrain	Chassis Control Module																																																												
T	2015	Colorado	Powertrain	Transfer Case Control Module																																																												
T	2015	Colorado	Chassis	Electronic Brake Control Module																																																												
T	2015	Colorado	Chassis	Power Steering Control Module																																																												
T	2015	Colorado	Body	Body Control Module																																																												
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2015	Colorado	Body	Passenger Presence Module																																																												
T	2015	Colorado	Body	Radio																																																											
T	2015	Colorado	Body	Amplifier																																																											
T	2015	Colorado	Body	Human Machine Interface Control Module																																																											
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																																											
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																											
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																											
T	2015	Colorado	Body	Frontview Camera Module																																																											
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																											
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																											
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2015	Colorado (MMM)	Body	Body Control Module																																																											
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2015	Colorado (MMM)	Body	Instrument Cluster																																																											
T	2015	Colorado (MMM)	Body	Radio																																																											
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																											
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																											
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																												V															
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																												V															
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																													
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																													
T	2015	S10	Powertrain	Transfer Case Control Module																																																													
T	2015	S10	Chassis	Electronic Brake Control Module																																																													
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2015	S10	Body	Body Control Module																																																													
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2015	S10	Body	Instrument Cluster																																																													
T	2015	S10	Body	Trailer Interface Control Module																																																													
T	2015	S10	Body	Radio																																																													
T	2015	S10	Body	Telematics Communication Interface Control Module																																																													
T	2015	S10	Body	Parking Assist Control Module																																																													
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																													
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																													
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																													
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																													
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																													
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																													
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																													
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																													
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																													
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2015	Trailblazer	Body	Body Control Module																																																													
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2015	Trailblazer	Body	Instrument Cluster																																																													
T	2015	Trailblazer	Body	Trailer Interface Control Module																																																													
T	2015	Trailblazer	Body	Radio																																																													
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																													
T	2015	Trailblazer	Body	Parking Assist Control Module																																																													
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																													
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																													
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																													
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																													
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																													
T	2016	Colorado (1GC)	Body	Body Control Module																																																													
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																																													
T	2016	Colorado (1GC)	Body	Radio Controls																																																													
T	2016	Colorado (1GC)	Body	HVAC Controls																																																													
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																													
T	2016	Colorado (1GC)	Body	Radio																																																													
T	2016	Colorado (1GC)	Body	Amplifier																																																													
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																												
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																												
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																												
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																												
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																												
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																												
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2016	Colorado (MMM)	Body	Body Control Module																																																												
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																												
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																												
T	2016	Colorado (MMM)	Body	Radio																																																												
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																												
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																												
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																												
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																												
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
T	2016	S10	Powertrain	Transfer Case Control Module																																																												
T	2016	S10	Chassis	Electronic Brake Control Module																																																												
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2016	S10	Body	Body Control Module																																																											
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	S10	Body	Instrument Cluster																																																												
T	2016	S10	Body	Trailer Interface Control Module																																																												
T	2016	S10	Body	Radio																																																											
T	2016	S10	Body	Telematics Communication Interface Control Module																																																												
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																												
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	S10	Body	Parking Assist Control Module																																																												
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																													
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																														
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																														
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																														
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																														
T	2016	Trailblazer	Body	Body Control Module																																																														
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
T	2016	Trailblazer	Body	Instrument Cluster																																																														
T	2016	Trailblazer	Body	Trailer Interface Control Module																																																														
T	2016	Trailblazer	Body	Radio																																																														
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																														
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																														
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																														
T	2016	Trailblazer	Body	Parking Assist Control Module																																																														
V	2009	ALL	Powertrain	Engine Control Module																																																														
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																														
V	2009	ALL	Powertrain	Rear Drive System																																																														
V	2009	ALL	Powertrain	Transmission Control Module																																																														
V	2009	ALL	Chassis	Electronic Brake Control Module																																																														
V	2009	ALL	Body	Body Control Module																																																														
V	2009	ALL	Body	Digital Radio Receiver																																																														
V	2009	ALL	Body	Driver Door Switch																																																														
V	2009	ALL	Body	Heated Seat Module																																																														
V	2009	ALL	Body	HVAC Control Module Auto																																																														
V	2009	ALL	Body	HVAC Control Module Manual																																																														
V	2009	ALL	Body	Instrument Panel Cluster																																																														
V	2009	ALL	Body	Lift Gate Module																																																														
V	2009	ALL	Body	Park Assist Module																																																														
V	2009	ALL	Body	Passenger Door Switch																																																														
V	2009	ALL	Body	Passenger Presence System																																																														
V	2009	ALL	Body	Radio																																																														
V	2009	ALL	Body	Rear HVAC/RSA																																																														
V	2009	ALL	Body	Rollover Sensor																																																														
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2009	ALL	Body	Theft Deterrent Module																																																														
V	2010	ALL	Powertrain	Engine Control Module																																																														
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																														
V	2010	ALL	Powertrain	Rear Drive System																																																														
V	2010	ALL	Powertrain	Transmission Control Module																																																														
V	2010	ALL	Chassis	Electronic Brake Control Module																																																														
V	2010	ALL	Body	Body Control Module																																																														
V	2010	ALL	Body	Digital Radio Receiver																																																														
V	2010	ALL	Body	Driver Door Switch																																																														
V	2010	ALL	Body	Heated Seat Module																																																														
V	2010	ALL	Body	HVAC Control Module Auto																																																														
V	2010	ALL	Body	HVAC Control Module Manual																																																														
V	2010	ALL	Body	Instrument Panel Cluster																																																														
V	2010	ALL	Body	Lift Gate Module																																																														
V	2010	ALL	Body	Park Assist Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
V	2010	ALL	Body	Passenger Door Switch																																																															
V	2010	ALL	Body	Passenger Presence System																																																															
V	2010	ALL	Body	Radio																																																															
V	2010	ALL	Body	Rear HVAC/RSA																																																															
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
V	2010	ALL	Body	Theft Deterrent Module																																																															
V	2011	ALL	Powertrain	Engine Control Module																																																															
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																															
V	2011	ALL	Powertrain	Rear Drive System																																																															
V	2011	ALL	Powertrain	Transmission Control Module																																																															
V	2011	ALL	Chassis	Electronic Brake Control Module																																																															
V	2011	ALL	Body	Body Control Module																																																															
V	2011	ALL	Body	Digital Radio Receiver																																																															
V	2011	ALL	Body	Driver Door Switch																																																															
V	2011	ALL	Body	Heated Seat Module																																																															
V	2011	ALL	Body	HVAC Control Module Auto																																																															
V	2011	ALL	Body	HVAC Control Module Manual																																																															
V	2011	ALL	Body	Instrument Panel Cluster																																																															
V	2011	ALL	Body	Lift Gate Module																																																															
V	2011	ALL	Body	Park Assist Module																																																															
V	2011	ALL	Body	Passenger Door Switch																																																															
V	2011	ALL	Body	Passenger Presence System																																																															
V	2011	ALL	Body	Radio																																																															
V	2011	ALL	Body	Rear HVAC/RSA																																																															
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																															
V	2011	ALL	Body	Theft Deterrent Module																																																															
V	2012	ALL	Powertrain	Engine Control Module																																																															
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																															
V	2012	ALL	Powertrain	Rear Drive System																																																															
V	2012	ALL	Powertrain	Transmission Control Module																																																															
V	2012	ALL	Chassis	Electronic Brake Control Module																																																															
V	2012	ALL	Body	Body Control Module																																																															
V	2012	ALL	Body	Digital Radio Receiver																																																															
V	2012	ALL	Body	Driver Door Switch																																																															
V	2012	ALL	Body	Heated Seat Module																																																															
V	2012	ALL	Body	HVAC Control Module Auto																																																															
V	2012	ALL	Body	HVAC Control Module Manual																																																															
V	2012	ALL	Body	Instrument Panel Cluster																																																															
V	2012	ALL	Body	Lift Gate Module																																																															
V	2012	ALL	Body	Park Assist Module																																																															
V	2012	ALL	Body	Passenger Door Switch																																																															
V	2012	ALL	Body	Passenger Presence System																																																															
V	2012	ALL	Body	Radio																																																															
V	2012	ALL	Body	Rear HVAC/RSA																																																															
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																															
V	2012	ALL	Body	Theft Deterrent Module																																																															
V	2013	ALL	Powertrain	Engine Control Module																																																															
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																															
V	2013	ALL	Powertrain	Rear Drive System																																																															
V	2013	ALL	Powertrain	Transmission Control Module																																																															
V	2013	ALL	Chassis	Electronic Brake Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
V	2013	ALL	Body	Body Control Module																																																														
V	2013	ALL	Body	Digital Radio Receiver																																																															
V	2013	ALL	Body	Driver Door Switch																																																															
V	2013	ALL	Body	Heated Seat Module																																																															
V	2013	ALL	Body	HVAC Control Module Auto																																																															
V	2013	ALL	Body	HVAC Control Module Manual																																																															
V	2013	ALL	Body	Instrument Panel Cluster																																																															
V	2013	ALL	Body	Left Side Object Detection Module																																																															
V	2013	ALL	Body	Lift Gate Module																																																															
V	2013	ALL	Body	Park Assist Module																																																															
V	2013	ALL	Body	Passenger Door Switch																																																															
V	2013	ALL	Body	Passenger Presence System																																																															
V	2013	ALL	Body	Radio																																																															
V	2013	ALL	Body	Rear HVAC/RSA																																																															
V	2013	ALL	Body	Right Side Object Detection Module																																																															
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																															
V	2013	ALL	Body	Theft Deterrent Module																																																															
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																															
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																															
V	2014	Traverse	Powertrain	Chassis Control Module																																																															
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																															
V	2014	Traverse	Chassis	Electronic Brake Control Module																																																															
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																															
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																															
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
V	2014	Traverse	Body	Passenger Presence Module																																																															
V	2014	Traverse	Body	Instrument Cluster																																																															
V	2014	Traverse	Body	Radio																																																															
V	2014	Traverse	Body	Rear Audio Control Module																																																															
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																															
V	2014	Traverse	Body	Personal Audio Link Control Module																																																															
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																															
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																															
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																															
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																															
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																															
V	2014	Traverse	Body	Liftgate Control Module																																																															
V	2014	Traverse	Body	Seat Memory Control Module																																																															
V	2014	Traverse	Body	Front Seat Heating Control Module																																																															
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																															
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																															
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																															
V	2014	Traverse	Body	Parking Assist Control Module																																																															
V	2014	Traverse	Body	Frontview Camera Module																																																															
V	2014	Traverse	Body	Theft Deterrent Module																																																															
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																															
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																															
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																															
V	2015	Traverse	Chassis	Electronic Brake Control Module																																																															
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																											
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2015	Traverse	Body	Passenger Presence Module																																																												
V	2015	Traverse	Body	Instrument Cluster																																																												
V	2015	Traverse	Body	Radio																																																												
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																												
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																												
V	2015	Traverse	Body	Liftgate Control Module																																																												
V	2015	Traverse	Body	Seat Memory Control Module																																																												
V	2015	Traverse	Body	Front Seat Heating Control Module																																																												
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																												
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																												
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																												
V	2015	Traverse	Body	Parking Assist Control Module																																																												
V	2015	Traverse	Body	Frontview Camera Module																																																												
V	2015	Traverse	Body	Theft Deterrent Module																																																												
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
V	2016	Traverse	Chassis	Electronic Brake Control Module																																																												
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																												
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																												
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2016	Traverse	Body	Passenger Presence Module																																																												
V	2016	Traverse	Body	Instrument Cluster																																																												
V	2016	Traverse	Body	Radio																																																												
V	2016	Traverse	Body	Rear Audio Control Module																																																												
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																												
V	2016	Traverse	Body	Personal Audio Link Control Module																																																												
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																												
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																												
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																												
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																												
V	2016	Traverse	Body	Liftgate Control Module																																																												
V	2016	Traverse	Body	Seat Memory Control Module																																																												
V	2016	Traverse	Body	Front Seat Heating Control Module																																																												
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																												
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																												
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																												
V	2016	Traverse	Body	Parking Assist Control Module																																																												
V	2016	Traverse	Body	Frontview Camera Module																																																												
V	2016	Traverse	Body	Theft Deterrent Module																																																												
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																												
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																														
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																															
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																															
A	2011	Orlando	Chassis	Parking Brake Control Module																																																															
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																															
A	2011	Orlando	Chassis	Power Steering Control Module																																																															
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																															
A	2011	Orlando	Body	Body Control Module																																																															
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
A	2011	Orlando	Body	Instrument Cluster																																																															
A	2011	Orlando	Body	Trailer Interface Control Module																																																															
A	2011	Orlando	Body	Radio																																																															
A	2011	Orlando	Body	Multimedia Player Interface Module																																																															
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																															
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																															
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																															
A	2011	Orlando	Body	Keyless Entry Control Module																																																															
A	2011	Orlando	Body	Parking Assist Control Module																																																															
A	2011	Orlando	Body	Steering Column Lock Control Module																																																															
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																															
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																															
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																															
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																															
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																															
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																															
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																	V	V	V		V			
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																	V	V	V		V			
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																															
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																															
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																															
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																															
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																															
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																															
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																															
A	2012	Orlando	Chassis	Parking Brake Control Module																																																															
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																															
A	2012	Orlando	Chassis	Power Steering Control Module																																																															
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																															
A	2012	Orlando	Body	Body Control Module																																																															
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
A	2012	Orlando	Body	Instrument Cluster																																																															
A	2012	Orlando	Body	Trailer Interface Control Module																																																															
A	2012	Orlando	Body	Radio																																																															
A	2012	Orlando	Body	Multimedia Player Interface Module																																																															
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																															
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																															
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																															
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																															
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																															
A	2012	Orlando	Body	Keyless Entry Control Module																																																															
A	2012	Orlando	Body	Parking Assist Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2012	Orlando	Body	Steering Column Lock Control Module																																																											
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																															V	V	V		V				
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																															V	V	V		V				
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																											
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																											
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																											
A	2013	Orlando	Chassis	Parking Brake Control Module																																																										
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Orlando	Chassis	Power Steering Control Module																																																										
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	Orlando	Body	Body Control Module																																																										
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	Orlando	Body	Instrument Cluster																																																										
A	2013	Orlando	Body	Radio																																																										
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2013	Orlando	Body	Multimedia Player Interface Module																																																										
A	2013	Orlando	Body	Mobile Telephone Control Module																																																										
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2013	Orlando	Body	Front Seat Heating Control Module																																																										
A	2013	Orlando	Body	Keyless Entry Control Module																																																										
A	2013	Orlando	Body	Parking Assist Control Module																																																										
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																										V																
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																										V																
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																															V	V	V		V				
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																															V	V	V		V				

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																											
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																											
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2014	Orlando	Chassis	Power Steering Control Module																																																											
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2014	Orlando	Body	Body Control Module																																																											
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2014	Orlando	Body	Instrument Cluster																																																											
A	2014	Orlando	Body	Radio																																																											
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																											
A	2014	Orlando	Body	Multimedia Player Interface Module																																																											
A	2014	Orlando	Body	Mobile Telephone Control Module																																																											
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																											
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																											
A	2014	Orlando	Body	Front Seat Heating Control Module																																																											
A	2014	Orlando	Body	Rear Seat Heating Control Module																																																											
A	2014	Orlando	Body	Keyless Entry Control Module																																																											
A	2014	Orlando	Body	Parking Assist Control Module																																																											
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																											
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																	V	V	V		V				
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																	V	V	V		V				
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																											
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																											
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																											
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																											
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2015	Orlando	Chassis	Power Steering Control Module																																																											
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2015	Orlando	Body	Body Control Module																																																											
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2015	Orlando	Body	Instrument Cluster																																																											
A	2015	Orlando	Body	Radio																																																											
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																											
A	2015	Orlando	Body	Mobile Telephone Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																														
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																														
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																														
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																														
A	2015	Orlando	Body	Front Seat Heating Control Module																																																														
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																														
A	2015	Orlando	Body	Keyless Entry Control Module																																																														
A	2015	Orlando	Body	Parking Assist Control Module																																																														
A	2015	Orlando	Body	Frontview Camera Module																																																														
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																														
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																														
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																														
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																														
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																														
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																														
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																														
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																														
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																														
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																V	V	V		V				
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																V	V	V		V				
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																														
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																														
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																														
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																														
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																														
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																														
A	2016	Orlando	Chassis	Power Steering Control Module																																																														
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																														
A	2016	Orlando	Body	Body Control Module																																																														
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
A	2016	Orlando	Body	Instrument Cluster																																																														
A	2016	Orlando	Body	Radio																																																														
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																														
A	2016	Orlando	Body	Multimedia Player Interface Module																																																														
A	2016	Orlando	Body	Mobile Telephone Control Module																																																														
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																														
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																														
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																														
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																														
A	2016	Orlando	Body	Front Seat Heating Control Module																																																														
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																														
A	2016	Orlando	Body	Keyless Entry Control Module																																																														
A	2016	Orlando	Body	Parking Assist Control Module																																																														
A	2016	Orlando	Body	Frontview Camera Module																																																														
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																																																														
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																																																														
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																																																														
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																																																														
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																																																														
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																														
C	2009	N200	Chassis	Electronic Brake Control Module																																																														
C	2009	N200	Body	Supplemental Inflatable Restraint																																																														
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																														
C	2009	N300	Chassis	Electronic Brake Control Module																																																														
C	2009	N300	Body	Supplemental Inflatable Restraint																																																														
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																														
C	2010	N200	Chassis	Electronic Brake Control Module																																																														
C	2010	N200	Body	Supplemental Inflatable Restraint																																																														
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																														
C	2010	N300	Chassis	Electronic Brake Control Module																																																														
C	2010	N300	Body	Supplemental Inflatable Restraint																																																														
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																														
C	2011	N200	Chassis	Electronic Brake Control Module																																																														
C	2011	N200	Body	Supplemental Inflatable Restraint																																																														
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																														
C	2011	N300	Chassis	Electronic Brake Control Module																																																														
C	2011	N300	Body	Supplemental Inflatable Restraint																																																														
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																														
C	2012	N200	Chassis	Electronic Brake Control Module																																																														
C	2012	N200	Body	Supplemental Inflatable Restraint																																																														
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																														
C	2012	N300	Chassis	Electronic Brake Control Module																																																														
C	2012	N300	Body	Supplemental Inflatable Restraint																																																														
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module																																																														
C	2013	N300	Chassis	Electronic Brake Control Module																																																														
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module																																																														
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																																														
C	2014	N300	Chassis	Electronic Brake Control Module																																																														
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module																																																														
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																																														
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																																														
C	2015	Max	Chassis	Electronic Brake Control Module																																																														
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module																																																														
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																																														
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																																														
C	2015	Move	Chassis	Electronic Brake Control Module																																																														
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module																																																														
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																																														
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																																														
C	2015	N300	Chassis	Electronic Brake Control Module																																																														
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module																																																														
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																																														
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																																														
C	2016	Max	Chassis	Electronic Brake Control Module																																																														
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module																																																														
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																																														
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																																														
C	2016	Move	Chassis	Electronic Brake Control Module																																																														
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module																																																														
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																																														
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																																														
C	2016	N300	Chassis	Electronic Brake Control Module																																																														
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																														
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																														
M	2015	City Express	Chassis	Electronic Brake Control Module																																																														
M	2015	City Express	Chassis	Power Steering Control Module																																																														
M	2015	City Express	Body	Body Control Module																																																														
M	2015	City Express	Body	Underhood Fuse Block																																																														
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2015	City Express	Body	Instrument Cluster																																																														
M	2015	City Express	Body	Tire Pressure Indicator Module																																																														
M	2015	City Express	Body	Radio																																																														
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																														
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																														
M	2016	City Express	Chassis	Electronic Brake Control Module																																																														
M	2016	City Express	Chassis	Power Steering Control Module																																																														
M	2016	City Express	Body	Body Control Module																																																														
M	2016	City Express	Body	Underhood Fuse Block																																																														
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
M	2016	City Express	Body	Instrument Cluster																																																														
M	2016	City Express	Body	Tire Pressure Indicator Module																																																														
M	2016	City Express	Body	Radio																																																														
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																														
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																														
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																														
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																	V	V	V		V				
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																	V	V	V		V				
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																														
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																														
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																														
P	2011	Orlando	Chassis	Parking Brake Control Module																																																														
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																														
P	2011	Orlando	Chassis	Power Steering Control Module																																																														
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
P	2011	Orlando	Body	Body Control Module																																																																	
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																	
P	2011	Orlando	Body	Instrument Cluster																																																																	
P	2011	Orlando	Body	Trailer Interface Control Module																																																																	
P	2011	Orlando	Body	Radio																																																																	
P	2011	Orlando	Body	Multimedia Player Interface Module																																																																	
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																																	
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																																	
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																																	
P	2011	Orlando	Body	Keyless Entry Control Module																																																																	
P	2011	Orlando	Body	Parking Assist Control Module																																																																	
P	2011	Orlando	Body	Steering Column Lock Control Module																																																																	
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																																	
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																																	
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																																	
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																																	
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																																	
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																																	
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																																	
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																																	
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																																	
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																																	
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																																	
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																																	
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																																	
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																																																	
P	2012	Orlando	Chassis	Electronic Brake Control Module																																																																	
P	2012	Orlando	Chassis	Parking Brake Control Module																																																																	
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																																	
P	2012	Orlando	Chassis	Power Steering Control Module																																																																	
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																																	
P	2012	Orlando	Body	Body Control Module																																																																	
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																	
P	2012	Orlando	Body	Instrument Cluster																																																																	
P	2012	Orlando	Body	Trailer Interface Control Module																																																																	
P	2012	Orlando	Body	Radio																																																																	
P	2012	Orlando	Body	Multimedia Player Interface Module																																																																	
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																																	
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																																	
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																																	
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																																	
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																																	
P	2012	Orlando	Body	Keyless Entry Control Module																																																																	
P	2012	Orlando	Body	Parking Assist Control Module																																																																	
P	2012	Orlando	Body	Steering Column Lock Control Module																																																																	
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																																	
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																																	
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																																	
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																																	
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																																	
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																																	

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																													
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																														
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																														
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																														
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																															V	V	V		V								
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																															V	V	V		V								
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																														
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																														
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																														
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																														
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																														
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																														
P	2013	Orlando	Chassis	Parking Brake Control Module																																																														
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																														
P	2013	Orlando	Chassis	Power Steering Control Module																																																														
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																														
P	2013	Orlando	Body	Body Control Module																																																														
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
P	2013	Orlando	Body	Instrument Cluster																																																														
P	2013	Orlando	Body	Radio																																																														
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																														
P	2013	Orlando	Body	Multimedia Player Interface Module																																																														
P	2013	Orlando	Body	Mobile Telephone Control Module																																																														
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																														
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																														
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																														
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																														
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																														
P	2013	Orlando	Body	Front Seat Heating Control Module																																																														
P	2013	Orlando	Body	Keyless Entry Control Module																																																														
P	2013	Orlando	Body	Parking Assist Control Module																																																														
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																											V																		
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																											V																		
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																														
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																														
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																														
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																														
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																														
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																														
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																														
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																														
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																														
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																															V	V	V		V								
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																															V	V	V		V								
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																														
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																														
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																														
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																														
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																														
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
P	2014	Orlando	Chassis	Power Steering Control Module																																																															
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																															
P	2014	Orlando	Body	Body Control Module																																																															
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
P	2014	Orlando	Body	Instrument Cluster																																																															
P	2014	Orlando	Body	Radio																																																															
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																															
P	2014	Orlando	Body	Multimedia Player Interface Module																																																															
P	2014	Orlando	Body	Mobile Telephone Control Module																																																															
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																															
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																															
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																															
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																															
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																															
P	2014	Orlando	Body	Front Seat Heating Control Module																																																															
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																															
P	2014	Orlando	Body	Keyless Entry Control Module																																																															
P	2014	Orlando	Body	Parking Assist Control Module																																																															
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																															
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																															
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																															
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																															
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																															
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																															
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																															
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																															
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																															
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																															
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																															
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																															
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																															
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																															
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																															
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																															
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																															
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																															
P	2015	Orlando	Chassis	Power Steering Control Module																																																															
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																															
P	2015	Orlando	Body	Body Control Module																																																															
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
P	2015	Orlando	Body	Instrument Cluster																																																															
P	2015	Orlando	Body	Radio																																																															
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																															
P	2015	Orlando	Body	Mobile Telephone Control Module																																																															
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																															
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																															
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																															
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																															
P	2015	Orlando	Body	Front Seat Heating Control Module																																																															
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																															
P	2015	Orlando	Body	Keyless Entry Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
P	2015	Orlando	Body	Parking Assist Control Module																																																															
P	2015	Orlando	Body	Frontview Camera Module																																																															
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																															
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																															
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																															
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																															
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																															
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																															
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																															
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																															
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																															
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																															
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																															
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																V	V	V		V				
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																V	V	V		V				
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																															
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																															
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																															
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																															
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																															
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																															
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																															
P	2016	Orlando	Chassis	Power Steering Control Module																																																															
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																															
P	2016	Orlando	Body	Body Control Module																																																															
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
P	2016	Orlando	Body	Instrument Cluster																																																															
P	2016	Orlando	Body	Radio																																																															
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																															
P	2016	Orlando	Body	Multimedia Player Interface Module																																																															
P	2016	Orlando	Body	Mobile Telephone Control Module																																																															
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																																															
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																															
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																															
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																															
P	2016	Orlando	Body	Front Seat Heating Control Module																																																															
P	2016	Orlando	Body	Rear Seat Heating Control Module																																																															
P	2016	Orlando	Body	Keyless Entry Control Module																																																															
P	2016	Orlando	Body	Parking Assist Control Module																																																															
P	2016	Orlando	Body	Frontview Camera Module																																																															
U	2004	ALL	Powertrain	Engine Control Module																																																															
U	2004	ALL	Powertrain	Transmission Control Module																																																															
U	2004	ALL	Body	Digital Radio Receiver																																																															
U	2004	ALL	Body	Driver Information Center																																																															
U	2004	ALL	Body	Instrument Panel Cluster																																																															
U	2004	ALL	Body	Radio																																																															
U	2004	ALL	Body	Supplemental Inflatable Restraint											V																																																			
U	2004	ALL	Body	Vehicle Theft Deterrent																																																															
U	2005	ALL	Powertrain	Engine Control Module																																																															
U	2005	ALL	Powertrain	Transmission Control Module																																																															
U	2005	ALL	Chassis	Electronic Brake Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
U	2005	ALL	Body	Body Control Module																																																														
U	2005	ALL	Body	Disc Player and Video																																																															
U	2005	ALL	Body	Digital Radio Receiver																																																														
U	2005	ALL	Body	HVAC Control Module																																																														
U	2005	ALL	Body	Instrument Panel Cluster																																																														
U	2005	ALL	Body	Left Power Sliding Door Module																																																														
U	2005	ALL	Body	Mobile Digital Media																																																														
U	2005	ALL	Body	Navigation Radio																																																														
U	2005	ALL	Body	Navigation Radio																																																														
U	2005	ALL	Body	Radio																																																														
U	2005	ALL	Body	Right Power Sliding Door Module																																																														
U	2005	ALL	Body	Supplemental Inflatable Restraint											V																																																			
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																															
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																															
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module												V																																																		
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																															
U	2006	ALL	Chassis	Electronic Brake Control Module																																																															
U	2006	ALL	Body	Body Control Module																																																															
U	2006	ALL	Body	Disc Player and Video																																																															
U	2006	ALL	Body	Digital Radio Receiver																																																															
U	2006	ALL	Body	HVAC Control Module																																																															
U	2006	ALL	Body	Instrument Panel Cluster																																																															
U	2006	ALL	Body	Left Power Sliding Door Module																																																															
U	2006	ALL	Body	Mobile Digital Media																																																															
U	2006	ALL	Body	Navigation Radio																																																															
U	2006	ALL	Body	Navigation Radio																																																															
U	2006	ALL	Body	Radio																																																															
U	2006	ALL	Body	Right Power Sliding Door Module																																																															
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																															
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																															
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																															
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																															
U	2007	ALL	Chassis	Electronic Brake Control Module																																																															
U	2007	ALL	Body	Body Control Module																																																															
U	2007	ALL	Body	Digital Radio Receiver																																																															
U	2007	ALL	Body	Disc Player and Video Display																																																															
U	2007	ALL	Body	HVAC Control Module																																																															
U	2007	ALL	Body	Left Power Sliding Door Module																																																															
U	2007	ALL	Body	Mobile Digital Media																																																															
U	2007	ALL	Body	Radio																																																															
U	2007	ALL	Body	Navigation Radio																																																															
U	2007	ALL	Body	Right Power Sliding Door Module																																																															
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																															
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																															
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																															
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																															
U	2008	ALL	Chassis	Electronic Brake Control Module																																																															
U	2008	ALL	Body	Body Control Module																																																															
U	2008	ALL	Body	Digital Radio Receiver																																																															
U	2008	ALL	Body	Disc Player and Video Display																																																															
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																															
U	2008	ALL	Body	Left Power Sliding Door Module																																																															
U	2008	ALL	Body	Radio																																																															
U	2008	ALL	Body	Navigation Radio																																																															
U	2008	ALL	Body	Remote Control Door Lock Receiver																																																															
U	2008	ALL	Body	Right Power Sliding Door Module																																																															
U	2009	ALL	Powertrain	Engine Control Module																																																															
U	2009	ALL	Powertrain	Transmission Control Module																																																															
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																															
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																															
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																															
U	2009	ALL	Body	Body Control Module																																																															
U	2009	ALL	Body	Digital Radio Receiver																																																															
U	2009	ALL	Body	Disc Player and Video Display																																																															
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																																															
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																															
U	2009	ALL	Body	Instrument Panel Cluster																																																															
U	2009	ALL	Body	Left Power Sliding Door Module																																																															
U	2009	ALL	Body	Radio																																																															
U	2009	ALL	Body	Remote Control Door Lock Receiver																																																															
U	2009	ALL	Body	Right Power Sliding Door Module																																																															
V	2004	ALL	Powertrain	Engine Data Display																																																															
V	2004	ALL	Powertrain	Transmission Data Display																																																															
V	2004	ALL	Body	Digital Radio Receiver																																																															
V	2004	ALL	Body	Driver Information Center																																																															
V	2004	ALL	Body	Instrument Panel Cluster																																																															
V	2004	ALL	Body	Radio																																																															
V	2004	ALL	Body	Supplemental Inflatable Restraint											V																																																				
V	2004	ALL	Body	Vehicle Theft Deterrent																																																															
V	2005	Venture	Powertrain	Engine Control Module																																																															
V	2005	Venture	Powertrain	Transmission Control Module																																																															
V	2005	Venture	Body	Digital Radio Receiver																																																															
V	2005	Venture	Body	Driver Information Center																																																															
V	2005	Venture	Body	Instrument Panel Cluster																																																															
V	2005	Venture	Body	Radio																																																															
V	2005	Venture	Body	Supplemental Inflatable Restraint											V																																																				
V	2005	Venture	Body	Vehicle Theft Deterrent																																																															
V	2005	Uplander	Powertrain	Engine Control Module																																													V																		
V	2005	Uplander	Powertrain	Transmission Control Module																																																															
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																															
V	2005	Uplander	Body	Body Control Module																																																															
V	2005	Uplander	Body	Disc Player and Video																																																															
V	2005	Uplander	Body	Digital Radio Receiver																																																															
V	2005	Uplander	Body	HVAC Control Module																																																															
V	2005	Uplander	Body	Instrument Panel Cluster																																																															
V	2005	Uplander	Body	Left Power Sliding Door Module																																																															
V	2005	Uplander	Body	Mobile Digital Media																																																															
V	2005	Uplander	Body	Navigation Radio																																																															
V	2005	Uplander	Body	Navigation Radio																																																															
V	2005	Uplander	Body	Radio																																																															
V	2005	Uplander	Body	Right Power Sliding Door Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
V	2005	Uplander	Body	Supplemental Inflatable Restraint											V																																																	
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																													V													
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																												
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module												V																																																
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																												
V	2006	ALL	Chassis	Electronic Brake Control Module																																																												
V	2006	ALL	Body	Body Control Module																																																											
V	2006	ALL	Body	Disc Player and Video																																																											
V	2006	ALL	Body	Digital Radio Receiver																																																											
V	2006	ALL	Body	HVAC Control Module																																																											
V	2006	ALL	Body	Instrument Panel Cluster																																																											
V	2006	ALL	Body	Left Power Sliding Door Module																																																											
V	2006	ALL	Body	Mobile Digital Media																																																											
V	2006	ALL	Body	Navigation Radio																																																											
V	2006	ALL	Body	Navigation Radio																																																											
V	2006	ALL	Body	Radio																																																											
V	2006	ALL	Body	Right Power Sliding Door Module																																																											
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																											
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																											
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																											
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																											
V	2007	ALL	Chassis	Electronic Brake Control Module																																																											
V	2007	ALL	Body	Body Control Module																																																											
V	2007	ALL	Body	Digital Radio Receiver																																																											
V	2007	ALL	Body	Disc Player and Video Display																																																											
V	2007	ALL	Body	HVAC Control Module																																																											
V	2007	ALL	Body	Left Power Sliding Door Module																																																											
V	2007	ALL	Body	Mobile Digital Media																																																											
V	2007	ALL	Body	Radio																																																											
V	2007	ALL	Body	Navigation Radio																																																											
V	2007	ALL	Body	Right Power Sliding Door Module																																																											
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																											
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																											
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																											
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																											
V	2008	ALL	Chassis	Electronic Brake Control Module																																																											
V	2008	ALL	Body	Body Control Module																																																											
V	2008	ALL	Body	Digital Radio Receiver																																																											
V	2008	ALL	Body	Disc Player and Video Display																																																											
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																																											
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																											
V	2008	ALL	Body	Left Power Sliding Door Module																																																											
V	2008	ALL	Body	Radio																																																											
V	2008	ALL	Body	Navigation Radio																																																											
V	2008	ALL	Body	Remote Control Door Lock Receiver																																																											
V	2008	ALL	Body	Right Power Sliding Door Module																																																											
V	2009	ALL	Powertrain	Engine Control Module																																																											
V	2009	ALL	Powertrain	Transmission Control Module																																																											
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																											
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																											
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
V	2009	ALL	Body	Body Control Module																																																															
V	2009	ALL	Body	Digital Radio Receiver																																																															
V	2009	ALL	Body	Disc Player and Video Display																																																															
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																																															
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																															
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																															
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																															
V	2009	ALL	Body	Left Power Sliding Door Module																																																															
V	2009	ALL	Body	Radio																																																															
V	2009	ALL	Body	Remote Control Door Lock Receiver																																																															
V	2009	ALL	Body	Right Power Sliding Door Module																																																															
X	2004	ALL	Powertrain	Engine Control Module																																																															
X	2004	ALL	Powertrain	Transmission Control Module																																																															
X	2004	ALL	Body	Digital Radio Receiver																																																															
X	2004	ALL	Body	Driver Information Center																																																															
X	2004	ALL	Body	Instrument Panel Cluster																																																															
X	2004	ALL	Body	Radio																																																															
X	2004	ALL	Body	Supplemental Inflatable Restraint											V																																																				
X	2004	ALL	Body	Vehicle Theft Deterrent																																																															
X	2005	ALL	Powertrain	Engine Control Module																																																V															
X	2005	ALL	Powertrain	Transmission Control Module																																																															
X	2005	ALL	Chassis	Electronic Brake Control Module																																																															
X	2005	ALL	Body	Body Control Module																																																															
X	2005	ALL	Body	Disc Player and Video																																																															
X	2005	ALL	Body	Digital Radio Receiver																																																															
X	2005	ALL	Body	HVAC Control Module																																																															
X	2005	ALL	Body	Instrument Panel Cluster																																																															
X	2005	ALL	Body	Left Power Sliding Door Module																																																															
X	2005	ALL	Body	Mobile Digital Media																																																															
X	2005	ALL	Body	Navigation Radio																																																															
X	2005	ALL	Body	Navigation Radio																																																															
X	2005	ALL	Body	Radio																																																															
X	2005	ALL	Body	Right Power Sliding Door Module																																																															
X	2005	ALL	Body	Supplemental Inflatable Restraint											V																																																				
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																V															
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																															
X	2006	ALL	Chassis	Electronic Brake Control Module																																																															
X	2006	ALL	Body	Body Control Module																																																															
X	2006	ALL	Body	Disc Player and Video																																																															
X	2006	ALL	Body	Digital Radio Receiver																																																															
X	2006	ALL	Body	HVAC Control Module																																																															
X	2006	ALL	Body	Instrument Panel Cluster																																																															
X	2006	ALL	Body	Left Power Sliding Door Module																																																															
X	2006	ALL	Body	Mobile Digital Media																																																															
X	2006	ALL	Body	Navigation Radio																																																															
X	2006	ALL	Body	Navigation Radio																																																															
X	2006	ALL	Body	Radio																																																															
X	2006	ALL	Body	Right Power Sliding Door Module																																																															

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2006	ALL	Powertrain	Transmission Control Module																																																										
A	2006	ALL	Chassis	Electronic Brake Control Module																																																										
A	2006	ALL	Chassis	Power Steering Control Module																																																										
A	2006	ALL	Body	Body Control Module																																																										
A	2006	ALL	Body	Digital Radio Receiver																																																										
A	2006	ALL	Body	Instrument Panel Cluster																																																										
A	2006	ALL	Body	Radio																																																										
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2006	ALL	Body	Theft Deterrent Module																																																										
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																										
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
A	2007	ALL	Chassis	Electronic Brake Control Module																																																										
A	2007	ALL	Chassis	Power Steering Control Module																																																										
A	2007	ALL	Body	Body Control Module																																																										
A	2007	ALL	Body	Digital Radio Receiver																																																										
A	2007	ALL	Body	Instrument Panel Cluster																																																										
A	2007	ALL	Body	Radio																																																										
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2007	ALL	Body	Theft Deterrent Module																																																										
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																										
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2008	HHR	Chassis	Power Steering Control Module																																																										
A	2008	HHR	Chassis	Power Steering Control Module																																																										
A	2008	HHR	Body	Body Control Module																																																										
A	2008	HHR	Body	Digital Radio Receiver																																																										
A	2008	HHR	Body	Instrument Panel Cluster																																																										
A	2008	HHR	Body	Radio																																																										
A	2008	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2008	HHR	Body	Theft Deterrent Module																																																										
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																										
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2008	HHR Panel	Body	Body Control Module																																																										
A	2008	HHR Panel	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																												
A	2008	HHR Panel	Body	Radio																																																												
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																																												
A	2008	HHR Panel	Body	Theft Deterrent Module																																																												
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																																												
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																																												
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																												
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																												
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																												
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																												
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																												
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																												
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																																												
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2009	HHR	Chassis	Power Steering Control Module																																																												
A	2009	HHR	Chassis	Power Steering Control Module																																																												
A	2009	HHR	Body	Body Control Module																																																												
A	2009	HHR	Body	Digital Radio Receiver																																																												
A	2009	HHR	Body	Instrument Panel Cluster																																																												
A	2009	HHR	Body	Radio																																																												
A	2009	HHR	Body	Supplemental Inflatable Restraint																																																												
A	2009	HHR	Body	Theft Deterrent Module																																																												
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																												
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																												
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																												
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																												
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																												
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																												
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																												
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2009	HHR Panel	Body	Body Control Module																																																												
A	2009	HHR Panel	Body	Digital Radio Receiver																																																												
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																												
A	2009	HHR Panel	Body	Radio																																																												
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																																												
A	2009	HHR Panel	Body	Theft Deterrent Module																																																												
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																												
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																												
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																												
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																												
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																												
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																												
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																																												
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2010	HHR	Chassis	Power Steering Control Module																																																												
A	2010	HHR	Chassis	Power Steering Control Module																																																												
A	2010	HHR	Body	Body Control Module																																																												
A	2010	HHR	Body	Digital Radio Receiver																																																												
A	2010	HHR	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2010	HHR	Body	Radio																																																											
A	2010	HHR	Body	Supplemental Inflatable Restraint																																																											
A	2010	HHR	Body	Theft Deterrent Module																																																											
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																											
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																											
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																											
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																											
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																											
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																											
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																											
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2010	HHR Panel	Body	Body Control Module																																																											
A	2010	HHR Panel	Body	Digital Radio Receiver																																																											
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																											
A	2010	HHR Panel	Body	Radio																																																											
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																																											
A	2010	HHR Panel	Body	Theft Deterrent Module																																																											
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																											
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																											
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																											
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																											
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																																											
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2011	HHR	Chassis	Power Steering Control Module																																																											
A	2011	HHR	Body	Body Control Module																																																											
A	2011	HHR	Body	Digital Radio Receiver																																																											
A	2011	HHR	Body	Instrument Panel Cluster																																																											
A	2011	HHR	Body	Radio																																																											
A	2011	HHR	Body	Supplemental Inflatable Restraint																																																											
A	2011	HHR	Body	Theft Deterrent Module																																																											
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																											
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																											
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																											
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																											
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																											
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2011	HHR Panel	Body	Body Control Module																																																											
A	2011	HHR Panel	Body	Digital Radio Receiver																																																											
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																											
A	2011	HHR Panel	Body	Radio																																																											
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																																											
A	2011	HHR Panel	Body	Theft Deterrent Module																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																												
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																												
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																												
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																												
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																												
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																												
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																												
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																												
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																												
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
A	2013	Trax	Chassis	Electronic Brake Control Module																																																												
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2013	Trax	Chassis	Power Steering Control Module																																																												
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2013	Trax	Body	Body Control Module																																																											
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2013	Trax	Body	Passenger Presence Module																																																												
A	2013	Trax	Body	Instrument Cluster																																																												
A	2013	Trax	Body	Radio																																																											
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																												
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
A	2013	Trax	Body	Front Seat Heating Control Module																																																												
A	2013	Trax	Body	Parking Assist Control Module																																																												
A	2013	Trax	Body	Frontview Camera Module																					V																																							
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																												
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																													
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																													
A	2014	Trax	Chassis	Electronic Brake Control Module																																																													
A	2014	Trax	Chassis	Power Steering Control Module																																																													
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2014	Trax	Body	Body Control Module																																																													
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2014	Trax	Body	Passenger Presence Module																																																													
A	2014	Trax	Body	Instrument Cluster																																																													
A	2014	Trax	Body	Radio																																																												
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																													
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																													
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																													
A	2014	Trax	Body	Front Seat Heating Control Module																																																													
A	2014	Trax	Body	Parking Assist Control Module																																																													
A	2014	Trax	Body	Frontview Camera Module																					V																																								
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																													
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																													
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																													
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																													
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																													
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																													
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																													
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																													
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																													
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																													
A	2015	Trax	Powertrain	Chassis Control Module																																																													
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																													
A	2015	Trax	Chassis	Electronic Brake Control Module																																																													
A	2015	Trax	Chassis	Power Steering Control Module																																																													
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2015	Trax	Body	Body Control Module																																																												
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2015	Trax	Body	Passenger Presence Module																																																												
A	2015	Trax	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2015	Trax	Body	Radio																																																											
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																												
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
A	2015	Trax	Body	Seat Memory Control Module																																																												
A	2015	Trax	Body	Front Seat Heating Control Module																																																												
A	2015	Trax	Body	Right Side Object Detection Control Module																																																												
A	2015	Trax	Body	Left Side Object Detection Control Module																																																												
A	2015	Trax	Body	Parking Assist Control Module																					V																																							
A	2015	Trax	Body	Frontview Camera Module																						V																																						
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																												
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																												
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																												
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																												
A	2016	Trax	Powertrain	Chassis Control Module																																																												
A	2016	Trax	Chassis	Electronic Brake Control Module																																																												
A	2016	Trax	Chassis	Power Steering Control Module																																																												
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2016	Trax	Body	Body Control Module																																																												
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2016	Trax	Body	Passenger Presence Module																																																												
A	2016	Trax	Body	Instrument Cluster																																																												
A	2016	Trax	Body	Trailer Interface Control Module																																																												
A	2016	Trax	Body	Radio																																																												
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																												
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
A	2016	Trax	Body	Seat Memory Control Module																																																												
A	2016	Trax	Body	Front Seat Heating Control Module																																																												
A	2016	Trax	Body	Right Side Object Detection Control Module																																																												
A	2016	Trax	Body	Left Side Object Detection Control Module																																																												
A	2016	Trax	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2016	Trax	Body	Frontview Camera Module																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																												V	V													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																												V	V													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																											
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																											
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																											
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																											
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																											
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
C	2004	ALL	Chassis	ESC																																																										
C	2004	ALL	Chassis	Rear Wheel Steering																																																											
C	2004	ALL	Chassis	Tire Pressure Monitor																																																											
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2004	ALL	Chassis	VSES																																																										
C	2004	ALL	Body	Amplifier (Bose)																																																											
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2004	ALL	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2004	ALL	Body	OnStar																																																											
C	2004	ALL	Body	Passenger Door Module																																																											
C	2004	ALL	Body	Passenger Presence System																																																											
C	2004	ALL	Body	Radio Base																																																											
C	2004	ALL	Body	Radio Uplevel																																																											
C	2004	ALL	Body	Radio Navigation																																																											
C	2004	ALL	Body	Rear Aux. Climate Module																																																												
C	2004	ALL	Body	Rear HVAC																																																											
C	2004	ALL	Body	Rear Seat Audio																																																											
C	2004	ALL	Body	Rear Seat Entertainment																																																											
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
C	2004	ALL	Body	Vehicle Theft Deterrent																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																														V	V											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																														V	V											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																											
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																											
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																											
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
C	2005	ALL	Chassis	ESC																																																											
C	2005	ALL	Chassis	Rear Wheel Steering																																																											
C	2005	ALL	Chassis	Tire Pressure Monitor																																																											
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2005	ALL	Chassis	VSES																																																											
C	2005	ALL	Body	Amplifier (Bose)																																																												
C	2005	ALL	Body	Body Control Module																																																												
C	2005	ALL	Body	CD Changer																																																												
C	2005	ALL	Body	Chime																																																												
C	2005	ALL	Body	Disc Player and Video Display																																																													
C	2005	ALL	Body	Driver Door Module																																																													
C	2005	ALL	Body	Driver Seat Module																																																													
C	2005	ALL	Body	Generator Battery Control Module																																																													
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																													
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																													
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																													
C	2005	ALL	Body	Instrument Panel Cluster																																																													
C	2005	ALL	Body	Passenger Door Module																																																													
C	2005	ALL	Body	Passenger Presence System																																																													
C	2005	ALL	Body	Base Radio																																																													
C	2005	ALL	Body	Uplevel Radio																																																													
C	2005	ALL	Body	Navigation Radio																																																													
C	2005	ALL	Body	Rear Aux. Climate Module																																																													
C	2005	ALL	Body	Rear HVAC																																																													
C	2005	ALL	Body	Rear Seat Audio																																																													
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																													
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																													
C	2005	ALL	Body	Vehicle Theft Deterrent																																																													
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																													
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																													
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																													
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																													
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																													
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																													
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																													
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																													
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																													
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																													
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																													
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																													
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																													
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																													
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																													
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																													
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																													
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																													
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																													
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																													
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																													
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																													
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																													
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																													
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																											
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																												
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																													
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
C	2006	ALL	Chassis	ESC																																																												
C	2006	ALL	Chassis	Tire Pressure Monitor																																																												
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2006	ALL	Chassis	VSES																																																												
C	2006	ALL	Body	Amplifier (Bose)																																																												
C	2006	ALL	Body	Body Control Module																																																												
C	2006	ALL	Body	CD Changer																																																												
C	2006	ALL	Body	Chime																																																												
C	2006	ALL	Body	Disc Player and Video Display																																																												
C	2006	ALL	Body	Driver Door Module																																																												
C	2006	ALL	Body	Driver Seat Module																																																												
C	2006	ALL	Body	Generator Battery Control Module																																																												
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																												
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
C	2006	ALL	Body	Instrument Panel Cluster																																																												
C	2006	ALL	Body	Passenger Door Module																																																												
C	2006	ALL	Body	Passenger Presence System																																																												
C	2006	ALL	Body	Base Radio																																																												
C	2006	ALL	Body	Uplevel Radio																																																												
C	2006	ALL	Body	Navigation Radio																																																												
C	2006	ALL	Body	Rear Aux. Climate Module																																																												
C	2006	ALL	Body	Rear HVAC																																																												
C	2006	ALL	Body	Rear Seat Audio																																																												
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2006	ALL	Body	Vehicle Theft Deterrent																																																												
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																												
C	2007	Avalanche	Body	Amplifier (Bose)																																																													
C	2007	Avalanche	Body	Assist Step Controller																																																													
C	2007	Avalanche	Body	Body Control Module																																																													
C	2007	Avalanche	Body	Body Control Module (aux.)																																																													
C	2007	Avalanche	Body	Digital Radio Receiver																																																													
C	2007	Avalanche	Body	Driver Door Switch																																																													
C	2007	Avalanche	Body	HVAC Control Module Auto																																																													
C	2007	Avalanche	Body	HVAC Control Module Manual																																																													
C	2007	Avalanche	Body	Instrument Panel Cluster																																																													
C	2007	Avalanche	Body	Memory Seat Module																																																													
C	2007	Avalanche	Body	Park Assist Module																																																													
C	2007	Avalanche	Body	Passenger Door Switch																																																													
C	2007	Avalanche	Body	Passenger Presence System																																																													
C	2007	Avalanche	Body	Radio																																																													
C	2007	Avalanche	Body	Rear Heated Seat Module																																																													
C	2007	Avalanche	Body	Rear HVAC/RSA																																																													
C	2007	Avalanche	Body	Rollover Sensor																																																													
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																													
C	2007	Avalanche	Body	Theft Deterrent Module																																																													
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																													
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2007	Suburban	Chassis	Electronic Suspension Control																																																													
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																													
C	2007	Suburban	Body	Amplifier (Bose)																																																													
C	2007	Suburban	Body	Assist Step Controller																																																													
C	2007	Suburban	Body	Body Control Module																																																													
C	2007	Suburban	Body	Body Control Module (aux.)																																																													
C	2007	Suburban	Body	Digital Radio Receiver																																																													
C	2007	Suburban	Body	Driver Door Switch																																																													
C	2007	Suburban	Body	HVAC Control Module Auto																																																													
C	2007	Suburban	Body	HVAC Control Module Manual																																																													
C	2007	Suburban	Body	Instrument Panel Cluster																																																													
C	2007	Suburban	Body	Lift Gate Module																																																													
C	2007	Suburban	Body	Memory Seat Module																																																													
C	2007	Suburban	Body	Park Assist Module																																																													
C	2007	Suburban	Body	Passenger Door Switch																																																													
C	2007	Suburban	Body	Passenger Presence System																																																													
C	2007	Suburban	Body	Radio																																																													
C	2007	Suburban	Body	Rear Heated Seat Module																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2007	Suburban	Body	Rear HVAC/RSA																																																											
C	2007	Suburban	Body	Rollover Sensor																																																												
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																																												
C	2007	Suburban	Body	Theft Deterrent Module																																																												
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Silverado	Chassis	Electronic Suspension Control																																																												
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																												
C	2007	Silverado	Body	Amplifier (Bose)																																																												
C	2007	Silverado	Body	Body Control Module																																																												
C	2007	Silverado	Body	Body Control Module (aux.)																																																												
C	2007	Silverado	Body	Digital Radio Receiver																																																												
C	2007	Silverado	Body	Driver Door Switch																																																												
C	2007	Silverado	Body	HVAC Control Module Auto																																																												
C	2007	Silverado	Body	HVAC Control Module Manual																																																												
C	2007	Silverado	Body	Instrument Panel Cluster																																																												
C	2007	Silverado	Body	Memory Seat Module																																																												
C	2007	Silverado	Body	Park Assist Module																																																												
C	2007	Silverado	Body	Passenger Door Switch																																																												
C	2007	Silverado	Body	Passenger Presence System																																																												
C	2007	Silverado	Body	Radio																																																												
C	2007	Silverado	Body	Rear Heated Seat Module																																																												
C	2007	Silverado	Body	Rear HVAC/RSA																																																												
C	2007	Silverado	Body	Rollover Sensor																																																												
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																																												
C	2007	Silverado	Body	Theft Deterrent Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2007	Tahoe	Body	Amplifier (Bose)																																																										
C	2007	Tahoe	Body	Assist Step Controller																																																										
C	2007	Tahoe	Body	Body Control Module																																																										
C	2007	Tahoe	Body	Body Control Module (aux.)																																																										
C	2007	Tahoe	Body	Digital Radio Receiver																																																										
C	2007	Tahoe	Body	Driver Door Switch																																																										
C	2007	Tahoe	Body	HVAC Control Module Auto																																																										
C	2007	Tahoe	Body	HVAC Control Module Manual																																																										
C	2007	Tahoe	Body	Instrument Panel Cluster																																																										
C	2007	Tahoe	Body	Lift Gate Module																																																										
C	2007	Tahoe	Body	Memory Seat Module																																																										
C	2007	Tahoe	Body	Park Assist Module																																																										
C	2007	Tahoe	Body	Passenger Door Switch																																																										
C	2007	Tahoe	Body	Passenger Presence System																																																										
C	2007	Tahoe	Body	Radio																																																										
C	2007	Tahoe	Body	Rear Heated Seat Module																																																										
C	2007	Tahoe	Body	Rear HVAC/RSA																																																										
C	2007	Tahoe	Body	Rollover Sensor																																																										
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2007	Tahoe	Body	Theft Deterrent Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2008	Avalanche	Body	Amplifier (Bose)																																																										
C	2008	Avalanche	Body	Assist Step Controller																																																										
C	2008	Avalanche	Body	Body Control Module																																																										
C	2008	Avalanche	Body	Body Control Module (aux.)																																																										
C	2008	Avalanche	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2008	Avalanche	Body	Driver Door Switch																																																											
C	2008	Avalanche	Body	HVAC Control Module Auto																																																												
C	2008	Avalanche	Body	HVAC Control Module Manual																																																												
C	2008	Avalanche	Body	Instrument Panel Cluster																																																												
C	2008	Avalanche	Body	Memory Seat Module																																																												
C	2008	Avalanche	Body	Park Assist Module																																																												
C	2008	Avalanche	Body	Passenger Door Switch																																																												
C	2008	Avalanche	Body	Passenger Presence System																																																												
C	2008	Avalanche	Body	Radio																																																											
C	2008	Avalanche	Body	Rear Heated Seat Module																																																												
C	2008	Avalanche	Body	Rear HVAC/RSA																																																												
C	2008	Avalanche	Body	Rollover Sensor																																																												
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																												
C	2008	Avalanche	Body	Theft Deterrent Module																																																												
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Suburban	Chassis	Electronic Suspension Control																																																												
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																												
C	2008	Suburban	Body	Amplifier (Bose)																																																												
C	2008	Suburban	Body	Assist Step Controller																																																												
C	2008	Suburban	Body	Body Control Module																																																												
C	2008	Suburban	Body	Body Control Module (aux.)																																																												
C	2008	Suburban	Body	Digital Radio Receiver																																																												
C	2008	Suburban	Body	Driver Door Switch																																																												
C	2008	Suburban	Body	HVAC Control Module Auto																																																												
C	2008	Suburban	Body	HVAC Control Module Manual																																																												
C	2008	Suburban	Body	Instrument Panel Cluster																																																												
C	2008	Suburban	Body	Lift Gate Module																																																												
C	2008	Suburban	Body	Memory Seat Module																																																												
C	2008	Suburban	Body	Park Assist Module																																																												
C	2008	Suburban	Body	Passenger Door Switch																																																												
C	2008	Suburban	Body	Passenger Presence System																																																												
C	2008	Suburban	Body	Radio																																																											
C	2008	Suburban	Body	Rear Heated Seat Module																																																												
C	2008	Suburban	Body	Rear HVAC/RSA																																																												
C	2008	Suburban	Body	Rollover Sensor																																																												
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2008	Suburban	Body	Theft Deterrent Module																																																											
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Silverado	Chassis	Electronic Suspension Control																																																												
C	2008	Silverado	Chassis	Trailer Brake Control Module																																																												
C	2008	Silverado	Body	Amplifier (Bose)																																																												
C	2008	Silverado	Body	Body Control Module																																																												
C	2008	Silverado	Body	Body Control Module (aux.)																																																												
C	2008	Silverado	Body	Digital Radio Receiver																																																												
C	2008	Silverado	Body	Driver Door Switch																																																												
C	2008	Silverado	Body	HVAC Control Module Auto																																																												
C	2008	Silverado	Body	HVAC Control Module Manual																																																												
C	2008	Silverado	Body	Instrument Panel Cluster																																																												
C	2008	Silverado	Body	Memory Seat Module																																																												
C	2008	Silverado	Body	Park Assist Module																																																												
C	2008	Silverado	Body	Passenger Door Switch																																																												
C	2008	Silverado	Body	Passenger Presence System																																																												
C	2008	Silverado	Body	Radio																																																											
C	2008	Silverado	Body	Rear Heated Seat Module																																																												
C	2008	Silverado	Body	Rear HVAC/RSA																																																												
C	2008	Silverado	Body	Rollover Sensor																																																												
C	2008	Silverado	Body	Supplemental Inflatable Restraint																																																												
C	2008	Silverado	Body	Theft Deterrent Module																																																												
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																																												
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																												
C	2008	Tahoe	Body	Amplifier (Bose)																																																												
C	2008	Tahoe	Body	Assist Step Controller																																																												
C	2008	Tahoe	Body	Body Control Module																																																												
C	2008	Tahoe	Body	Body Control Module (aux.)																																																												
C	2008	Tahoe	Body	Digital Radio Receiver																																																												
C	2008	Tahoe	Body	Driver Door Switch																																																												
C	2008	Tahoe	Body	HVAC Control Module Auto																																																												
C	2008	Tahoe	Body	HVAC Control Module Manual																																																												
C	2008	Tahoe	Body	Instrument Panel Cluster																																																												
C	2008	Tahoe	Body	Memory Seat Module																																																												
C	2008	Tahoe	Body	Park Assist Module																																																												
C	2008	Tahoe	Body	Passenger Presence System																																																												
C	2008	Tahoe	Body	Radio																																																												
C	2008	Tahoe	Body	Rear Heated Seat Module																																																												
C	2008	Tahoe	Body	Rear HVAC/RSA																																																												
C	2008	Tahoe	Body	Rollover Sensor																																																												
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2008	Tahoe	Body	Theft Deterrent Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2008	Tahoe Hybrid	Body	Body Control Module																																																												
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2008	Tahoe Hybrid	Body	HVAC Control Module																																																												
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2008	Tahoe Hybrid	Body	Memory Seat Module																																																												
C	2008	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2008	Tahoe Hybrid	Body	Radio																																																										
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																																										
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2009	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2009	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2009	Avalanche	Body	Amplifier (Bose)																																																										
C	2009	Avalanche	Body	Assist Step Controller																																																										
C	2009	Avalanche	Body	Body Control Module																																																										
C	2009	Avalanche	Body	Body Control Module (aux.)																																																										
C	2009	Avalanche	Body	Digital Radio Receiver																																																										
C	2009	Avalanche	Body	Driver Door Switch																																																										
C	2009	Avalanche	Body	HVAC Control Module Auto																																																										
C	2009	Avalanche	Body	HVAC Control Module Manual																																																										
C	2009	Avalanche	Body	Instrument Panel Cluster																																																										
C	2009	Avalanche	Body	Memory Seat Module																																																										
C	2009	Avalanche	Body	Park Assist Module																																																										
C	2009	Avalanche	Body	Passenger Door Switch																																																										
C	2009	Avalanche	Body	Passenger Presence System																																																										
C	2009	Avalanche	Body	Radio																																																										
C	2009	Avalanche	Body	Rear Heated Seat Module																																																										
C	2009	Avalanche	Body	Rear HVAC/RSA																																																										
C	2009	Avalanche	Body	Rollover Sensor																																																										
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2009	Avalanche	Body	Theft Deterrent Module																																																										
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																												
C	2009	Cheyenne	Body	Amplifier (Bose)																																																												
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																												
C	2009	Cheyenne	Body	Digital Radio Receiver																																																												
C	2009	Cheyenne	Body	Driver Door Switch																																																												
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																												
C	2009	Cheyenne	Body	Park Assist Module																																																												
C	2009	Cheyenne	Body	Passenger Door Switch																																																												
C	2009	Cheyenne	Body	Passenger Presence System																																																												
C	2009	Cheyenne	Body	Rear Heated Seat Module																																																												
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																												
C	2009	Cheyenne	Body	Rollover Sensor																																																												
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																												
C	2009	Cheyenne	Body	Theft Deterrent Module																																																												
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																												
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2009	Suburban	Chassis	Electronic Suspension Control																																																												
C	2009	Suburban	Chassis	Trailer Brake Control Module																																																												
C	2009	Suburban	Body	Amplifier (Bose)																																																												
C	2009	Suburban	Body	Assist Step Controller																																																												
C	2009	Suburban	Body	Body Control Module																																																												
C	2009	Suburban	Body	Body Control Module (aux.)																																																												
C	2009	Suburban	Body	Digital Radio Receiver																																																												
C	2009	Suburban	Body	Driver Door Switch																																																												
C	2009	Suburban	Body	HVAC Control Module Auto																																																												
C	2009	Suburban	Body	HVAC Control Module Manual																																																												
C	2009	Suburban	Body	Instrument Panel Cluster																																																												
C	2009	Suburban	Body	Left Side Object Detection Module																																																												
C	2009	Suburban	Body	Lift Gate Module																																																												
C	2009	Suburban	Body	Memory Seat Module																																																												
C	2009	Suburban	Body	Park Assist Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2009	Suburban	Body	Passenger Door Switch																																																											
C	2009	Suburban	Body	Passenger Presence System																																																												
C	2009	Suburban	Body	Radio																																																												
C	2009	Suburban	Body	Rear Heated Seat Module																																																												
C	2009	Suburban	Body	Rear HVAC/RSA																																																												
C	2009	Suburban	Body	Right Side Object Detection Module																																																												
C	2009	Suburban	Body	Rollover Sensor																																																												
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																																												
C	2009	Suburban	Body	Theft Deterrent Module																																																												
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2009	Silverado	Chassis	Electronic Suspension Control																																																												
C	2009	Silverado	Chassis	Trailer Brake Control Module																																																												
C	2009	Silverado	Body	Amplifier (Bose)																																																												
C	2009	Silverado	Body	Body Control Module																																																												
C	2009	Silverado	Body	Body Control Module (aux.)																																																												
C	2009	Silverado	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2009	Silverado	Body	Driver Door Switch																																																											
C	2009	Silverado	Body	HVAC Control Module Auto																																																												
C	2009	Silverado	Body	HVAC Control Module Manual																																																												
C	2009	Silverado	Body	Instrument Panel Cluster																																																												
C	2009	Silverado	Body	Memory Seat Module																																																												
C	2009	Silverado	Body	Park Assist Module																																																												
C	2009	Silverado	Body	Passenger Door Switch																																																												
C	2009	Silverado	Body	Passenger Presence System																																																												
C	2009	Silverado	Body	Radio																																																												
C	2009	Silverado	Body	Rear Heated Seat Module																																																												
C	2009	Silverado	Body	Rear HVAC/RSA																																																												
C	2009	Silverado	Body	Rollover Sensor																																																												
C	2009	Silverado	Body	Supplemental Inflatable Restraint																																																												
C	2009	Silverado	Body	Theft Deterrent Module																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																												
C	2009	Silverado Hybrid	Body	Body Control Module																																																												
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																												
C	2009	Silverado Hybrid	Body	Driver Door Switch																																																												
C	2009	Silverado Hybrid	Body	HVAC Control Module																																																												
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
C	2009	Silverado Hybrid	Body	Memory Seat Module																																																												
C	2009	Silverado Hybrid	Body	Park Assist Module																																																												
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																																												
C	2009	Silverado Hybrid	Body	Passenger Presence System																																																												
C	2009	Silverado Hybrid	Body	Radio																																																												
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
C	2009	Silverado Hybrid	Body	Rollover Sensor																																																												
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																												
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2009	Tahoe	Body	Amplifier (Bose)																																																										
C	2009	Tahoe	Body	Assist Step Controller																																																										
C	2009	Tahoe	Body	Body Control Module																																																										
C	2009	Tahoe	Body	Body Control Module (aux.)																																																										
C	2009	Tahoe	Body	Digital Radio Receiver																																																										
C	2009	Tahoe	Body	Driver Door Switch																																																										
C	2009	Tahoe	Body	HVAC Control Module Auto																																																										
C	2009	Tahoe	Body	HVAC Control Module Manual																																																										
C	2009	Tahoe	Body	Instrument Panel Cluster																																																										
C	2009	Tahoe	Body	Left Side Object Detection Module																																																										
C	2009	Tahoe	Body	Lift Gate Module																																																										
C	2009	Tahoe	Body	Memory Seat Module																																																										
C	2009	Tahoe	Body	Park Assist Module																																																										
C	2009	Tahoe	Body	Passenger Door Switch																																																										
C	2009	Tahoe	Body	Passenger Presence System																																																										
C	2009	Tahoe	Body	Radio																																																										
C	2009	Tahoe	Body	Rear Heated Seat Module																																																										
C	2009	Tahoe	Body	Rear HVAC/RSA																																																										
C	2009	Tahoe	Body	Right Side Object Detection Module																																																										
C	2009	Tahoe	Body	Rollover Sensor																																																										
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2009	Tahoe	Body	Theft Deterrent Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2009	Tahoe Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2009	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2009	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2009	Tahoe Hybrid	Body	Radio																																																										
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																										
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Avalanche	Body	Amplifier (Bose)																																																										
C	2010	Avalanche	Body	Assist Step Controller																																																										
C	2010	Avalanche	Body	Body Control Module																																																										
C	2010	Avalanche	Body	Body Control Module (aux.)																																																										
C	2010	Avalanche	Body	Digital Radio Receiver																																																										
C	2010	Avalanche	Body	Driver Door Switch																																																										
C	2010	Avalanche	Body	HVAC Control Module Auto																																																										
C	2010	Avalanche	Body	HVAC Control Module Manual																																																										
C	2010	Avalanche	Body	Instrument Panel Cluster																																																										
C	2010	Avalanche	Body	Memory Seat Module																																																										
C	2010	Avalanche	Body	Park Assist Module																																																										
C	2010	Avalanche	Body	Passenger Door Switch																																																										
C	2010	Avalanche	Body	Passenger Presence System																																																										
C	2010	Avalanche	Body	Radio																																																										
C	2010	Avalanche	Body	Rear Heated Seat Module																																																										
C	2010	Avalanche	Body	Rear HVAC/RSA																																																										
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2010	Avalanche	Body	Theft Deterrent Module																																																										
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																											
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Cheyenne	Body	Amplifier (Bose)																																																											
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																											
C	2010	Cheyenne	Body	Digital Radio Receiver																																																											
C	2010	Cheyenne	Body	Driver Door Switch																																																											
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																											
C	2010	Cheyenne	Body	Park Assist Module																																																											
C	2010	Cheyenne	Body	Passenger Door Switch																																																											
C	2010	Cheyenne	Body	Passenger Presence System																																																											
C	2010	Cheyenne	Body	Rear Heated Seat Module																																																											
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																											
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
C	2010	Cheyenne	Body	Theft Deterrent Module																																																											
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																											
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2010	Suburban	Chassis	Electronic Suspension Control																																																											
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Suburban	Body	Amplifier (Bose)																																																											
C	2010	Suburban	Body	Assist Step Controller																																																											
C	2010	Suburban	Body	Body Control Module																																																											
C	2010	Suburban	Body	Body Control Module (aux.)																																																											
C	2010	Suburban	Body	Digital Radio Receiver																																																											
C	2010	Suburban	Body	Driver Door Switch																																																											
C	2010	Suburban	Body	HVAC Control Module Auto																																																											
C	2010	Suburban	Body	HVAC Control Module Manual																																																											
C	2010	Suburban	Body	Instrument Panel Cluster																																																											
C	2010	Suburban	Body	Left Side Object Detection Module																																																											
C	2010	Suburban	Body	Lift Gate Module																																																											
C	2010	Suburban	Body	Memory Seat Module																																																											
C	2010	Suburban	Body	Park Assist Module																																																											
C	2010	Suburban	Body	Passenger Door Switch																																																											
C	2010	Suburban	Body	Passenger Presence System																																																											
C	2010	Suburban	Body	Radio																																																											
C	2010	Suburban	Body	Rear Heated Seat Module																																																											
C	2010	Suburban	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2010	Suburban	Body	Right Side Object Detection Module																																																											
C	2010	Suburban	Body	Supplemental Inflatable Restraint																																																												
C	2010	Suburban	Body	Theft Deterrent Module																																																												
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																												
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2010	Silverado	Chassis	Electronic Suspension Control																																																												
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2010	Silverado	Body	Amplifier (Bose)																																																												
C	2010	Silverado	Body	Body Control Module																																																												
C	2010	Silverado	Body	Body Control Module (aux.)																																																												
C	2010	Silverado	Body	Digital Radio Receiver																																																												
C	2010	Silverado	Body	Driver Door Switch																																																												
C	2010	Silverado	Body	HVAC Control Module Auto																																																												
C	2010	Silverado	Body	HVAC Control Module Manual																																																												
C	2010	Silverado	Body	Instrument Panel Cluster																																																												
C	2010	Silverado	Body	Memory Seat Module																																																												
C	2010	Silverado	Body	Park Assist Module																																																												
C	2010	Silverado	Body	Passenger Door Switch																																																												
C	2010	Silverado	Body	Passenger Presence System																																																												
C	2010	Silverado	Body	Radio																																																											
C	2010	Silverado	Body	Rear Heated Seat Module																																																												
C	2010	Silverado	Body	Rear HVAC/RSA																																																												
C	2010	Silverado	Body	Supplemental Inflatable Restraint																																																												
C	2010	Silverado	Body	Theft Deterrent Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2010	Silverado Hybrid	Body	Body Control Module																																																										
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2010	Silverado Hybrid	Body	HVAC Control Module																																																										
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2010	Silverado Hybrid	Body	Park Assist Module																																																										
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2010	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2010	Silverado Hybrid	Body	Radio																																																										
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																										
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Tahoe	Body	Amplifier (Bose)																																																										
C	2010	Tahoe	Body	Assist Step Controller																																																										
C	2010	Tahoe	Body	Body Control Module																																																										
C	2010	Tahoe	Body	Body Control Module (aux.)																																																										
C	2010	Tahoe	Body	Digital Radio Receiver																																																										
C	2010	Tahoe	Body	Driver Door Switch																																																										
C	2010	Tahoe	Body	HVAC Control Module Auto																																																										
C	2010	Tahoe	Body	HVAC Control Module Manual																																																										
C	2010	Tahoe	Body	Instrument Panel Cluster																																																										
C	2010	Tahoe	Body	Left Side Object Detection Module																																																										
C	2010	Tahoe	Body	Lift Gate Module																																																										
C	2010	Tahoe	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2010	Tahoe	Body	Park Assist Module																																																										
C	2010	Tahoe	Body	Passenger Door Switch																																																										
C	2010	Tahoe	Body	Passenger Presence System																																																										
C	2010	Tahoe	Body	Radio																																																										
C	2010	Tahoe	Body	Rear Heated Seat Module																																																										
C	2010	Tahoe	Body	Rear HVAC/RSA																																																										
C	2010	Tahoe	Body	Right Side Object Detection Module																																																										
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2010	Tahoe	Body	Theft Deterrent Module																																																										
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2010	Tahoe Hybrid	Body	Body Control Module																																																										
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2010	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2010	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2010	Tahoe Hybrid	Body	Radio																																																										
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2011	Avalanche	Body	Amplifier (Bose)																																																										
C	2011	Avalanche	Body	Assist Step Controller																																																										
C	2011	Avalanche	Body	Body Control Module																																																										
C	2011	Avalanche	Body	Body Control Module (aux.)																																																										
C	2011	Avalanche	Body	Digital Radio Receiver																																																										
C	2011	Avalanche	Body	Driver Door Switch																																																										
C	2011	Avalanche	Body	HVAC Control Module Auto																																																										
C	2011	Avalanche	Body	HVAC Control Module Manual																																																										
C	2011	Avalanche	Body	Instrument Panel Cluster																																																										
C	2011	Avalanche	Body	Memory Seat Module																																																										
C	2011	Avalanche	Body	Park Assist Module																																																										
C	2011	Avalanche	Body	Passenger Door Switch																																																										
C	2011	Avalanche	Body	Passenger Presence System																																																										
C	2011	Avalanche	Body	Radio																																																										
C	2011	Avalanche	Body	Rear Heated Seat Module																																																										
C	2011	Avalanche	Body	Rear HVAC/RSA																																																										
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2011	Avalanche	Body	Theft Deterrent Module																																																										
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																										
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2011	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2011	Captiva	Chassis	Parking Brake Control Module																																																										
C	2011	Captiva	Body	Body Control Module																																																										
C	2011	Captiva	Body	Auxiliary Body Control Module																																																										
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2011	Captiva	Body	Instrument Cluster																																																										
C	2011	Captiva	Body	Headlamp Control Module																																																										
C	2011	Captiva	Body	HVAC Control Module																																																										
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																										
C	2011	Captiva	Body	Parking Assist Control Module																				V																																						
C	2011	Captiva	Body	Theft Deterrent Module																																																										
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																										
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Cheyenne	Body	Amplifier (Bose)																																																										
C	2011	Cheyenne	Body	Body Control Module																																																										
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2011	Cheyenne	Body	Digital Radio Receiver																																																										
C	2011	Cheyenne	Body	Driver Door Switch																																																										
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2011	Cheyenne	Body	Park Assist Module																																																										
C	2011	Cheyenne	Body	Passenger Door Switch																																																										
C	2011	Cheyenne	Body	Passenger Presence System																																																										
C	2011	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2011	Cheyenne	Body	Theft Deterrent Module																																																										
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2011	Suburban	Chassis	Electronic Suspension Control																																																										
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Suburban	Body	Amplifier (Bose)																																																										
C	2011	Suburban	Body	Assist Step Controller																																																										
C	2011	Suburban	Body	Body Control Module																																																										
C	2011	Suburban	Body	Body Control Module (aux.)																																																										
C	2011	Suburban	Body	Digital Radio Receiver																																																										
C	2011	Suburban	Body	Driver Door Switch																																																										
C	2011	Suburban	Body	HVAC Control Module Auto																																																										
C	2011	Suburban	Body	HVAC Control Module Manual																																																										
C	2011	Suburban	Body	Instrument Panel Cluster																																																										
C	2011	Suburban	Body	Left Side Object Detection Module																																																										
C	2011	Suburban	Body	Lift Gate Module																																																										
C	2011	Suburban	Body	Memory Seat Module																																																										
C	2011	Suburban	Body	Park Assist Module																																																										
C	2011	Suburban	Body	Passenger Door Switch																																																										
C	2011	Suburban	Body	Passenger Presence System																																																										
C	2011	Suburban	Body	Radio																																																										
C	2011	Suburban	Body	Rear Heated Seat Module																																																										
C	2011	Suburban	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2011	Suburban	Body	Right Side Object Detection Module																																																											
C	2011	Suburban	Body	Supplemental Inflatable Restraint																																																												
C	2011	Suburban	Body	Theft Deterrent Module																																																												
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																												
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2011	Silverado	Chassis	Electronic Suspension Control																																																												
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2011	Silverado	Body	Amplifier (Bose)																																																												
C	2011	Silverado	Body	Body Control Module																																																												
C	2011	Silverado	Body	Body Control Module (aux.)																																																												
C	2011	Silverado	Body	Digital Radio Receiver																																																												
C	2011	Silverado	Body	Driver Door Switch																																																												
C	2011	Silverado	Body	HVAC Control Module Auto																																																												
C	2011	Silverado	Body	HVAC Control Module Manual																																																												
C	2011	Silverado	Body	Instrument Panel Cluster																																																												
C	2011	Silverado	Body	Memory Seat Module																																																												
C	2011	Silverado	Body	Park Assist Module																																																												
C	2011	Silverado	Body	Passenger Door Switch																																																												
C	2011	Silverado	Body	Passenger Presence System																																																												
C	2011	Silverado	Body	Radio																																																											
C	2011	Silverado	Body	Rear Heated Seat Module																																																												
C	2011	Silverado	Body	Rear HVAC/RSA																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2011	Silverado	Body	Theft Deterrent Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Silverado Hybrid	Body	Body Control Module																																																										
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2011	Silverado Hybrid	Body	HVAC Control Module																																																										
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Silverado Hybrid	Body	Park Assist Module																																																										
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2011	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2011	Silverado Hybrid	Body	Radio																																																										
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe	Body	Amplifier (Bose)																																																										
C	2011	Tahoe	Body	Assist Step Controller																																																										
C	2011	Tahoe	Body	Body Control Module																																																										
C	2011	Tahoe	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe	Body	Digital Radio Receiver																																																										
C	2011	Tahoe	Body	Driver Door Switch																																																										
C	2011	Tahoe	Body	HVAC Control Module Auto																																																										
C	2011	Tahoe	Body	HVAC Control Module Manual																																																										
C	2011	Tahoe	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe	Body	Left Side Object Detection Module																																																										
C	2011	Tahoe	Body	Lift Gate Module																																																										
C	2011	Tahoe	Body	Memory Seat Module																																																										
C	2011	Tahoe	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2011	Tahoe	Body	Passenger Door Switch																																																											
C	2011	Tahoe	Body	Passenger Presence System																																																												
C	2011	Tahoe	Body	Radio																																																												
C	2011	Tahoe	Body	Rear Heated Seat Module																																																												
C	2011	Tahoe	Body	Rear HVAC/RSA																																																												
C	2011	Tahoe	Body	Right Side Object Detection Module																																																												
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2011	Tahoe	Body	Theft Deterrent Module																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2011	Tahoe Hybrid	Body	Body Control Module																																																												
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																																												
C	2011	Tahoe Hybrid	Body	HVAC Control Module																																																												
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																																												
C	2011	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																												
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																																												
C	2011	Tahoe Hybrid	Body	Radio																																																												
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2012	Avalanche	Chassis	Electronic Brake Control Module																																																												
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																												
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2012	Avalanche	Body	Amplifier (Bose)																																																										
C	2012	Avalanche	Body	Assist Step Controller																																																										
C	2012	Avalanche	Body	Body Control Module																																																										
C	2012	Avalanche	Body	Body Control Module (aux.)																																																										
C	2012	Avalanche	Body	Digital Radio Receiver																																																										
C	2012	Avalanche	Body	Driver Door Switch																																																										
C	2012	Avalanche	Body	HVAC Control Module Auto																																																										
C	2012	Avalanche	Body	HVAC Control Module Manual																																																										
C	2012	Avalanche	Body	Instrument Panel Cluster																																																										
C	2012	Avalanche	Body	Memory Seat Module																																																										
C	2012	Avalanche	Body	Navigation Radio																																																										
C	2012	Avalanche	Body	Park Assist Module																																																										
C	2012	Avalanche	Body	Passenger Door Switch																																																										
C	2012	Avalanche	Body	Passenger Presence System																																																										
C	2012	Avalanche	Body	Radio																																																										
C	2012	Avalanche	Body	Rear Heated Seat Module																																																										
C	2012	Avalanche	Body	Rear HVAC/RSA																																																										
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2012	Avalanche	Body	Theft Deterrent Module																																																										
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2012	Captiva	Chassis	Parking Brake Control Module																																																										
C	2012	Captiva	Body	Body Control Module																																																										
C	2012	Captiva	Body	Auxiliary Body Control Module																																																										
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2012	Captiva	Body	Instrument Cluster																																																										
C	2012	Captiva	Body	Headlamp Control Module																																																										
C	2012	Captiva	Body	HVAC Control Module																																																										
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																										
C	2012	Captiva	Body	Parking Assist Control Module																				V																																						

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2012	Captiva	Body	Theft Deterrent Module																																																										
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																										
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Cheyenne	Body	Amplifier (Bose)																																																										
C	2012	Cheyenne	Body	Body Control Module																																																										
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2012	Cheyenne	Body	Digital Radio Receiver																																																										
C	2012	Cheyenne	Body	Driver Door Switch																																																										
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2012	Cheyenne	Body	Park Assist Module																																																										
C	2012	Cheyenne	Body	Passenger Door Switch																																																										
C	2012	Cheyenne	Body	Passenger Presence System																																																										
C	2012	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2012	Cheyenne	Body	Theft Deterrent Module																																																										
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																										
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2012	Suburban	Chassis	Electronic Suspension Control																																																										
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Suburban	Body	Amplifier (Bose)																																																										
C	2012	Suburban	Body	Assist Step Controller																																																										
C	2012	Suburban	Body	Body Control Module																																																										
C	2012	Suburban	Body	Body Control Module (aux.)																																																										
C	2012	Suburban	Body	Digital Radio Receiver																																																										
C	2012	Suburban	Body	Driver Door Switch																																																										
C	2012	Suburban	Body	HVAC Control Module Auto																																																										
C	2012	Suburban	Body	HVAC Control Module Manual																																																										
C	2012	Suburban	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2012	Suburban	Body	Left Side Object Detection Module																																																											
C	2012	Suburban	Body	Lift Gate Module																																																												
C	2012	Suburban	Body	Memory Seat Module																																																												
C	2012	Suburban	Body	Navigation Radio																																																												
C	2012	Suburban	Body	Park Assist Module																																																												
C	2012	Suburban	Body	Passenger Door Switch																																																												
C	2012	Suburban	Body	Passenger Presence System																																																												
C	2012	Suburban	Body	Radio																																																												
C	2012	Suburban	Body	Rear Heated Seat Module																																																												
C	2012	Suburban	Body	Rear HVAC/RSA																																																												
C	2012	Suburban	Body	Right Side Object Detection Module																																																												
C	2012	Suburban	Body	Supplemental Inflatable Restraint																																																												
C	2012	Suburban	Body	Theft Deterrent Module																																																												
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																												
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2012	Silverado	Chassis	Electronic Suspension Control																																																												
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2012	Silverado	Body	Amplifier (Bose)																																																												
C	2012	Silverado	Body	Body Control Module																																																												
C	2012	Silverado	Body	Body Control Module (aux.)																																																												
C	2012	Silverado	Body	Digital Radio Receiver																																																												
C	2012	Silverado	Body	Driver Door Switch																																																												
C	2012	Silverado	Body	HVAC Control Module Auto																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2012	Silverado	Body	HVAC Control Module Manual																																																										
C	2012	Silverado	Body	Instrument Panel Cluster																																																										
C	2012	Silverado	Body	Memory Seat Module																																																										
C	2012	Silverado	Body	Navigation Radio																																																										
C	2012	Silverado	Body	Park Assist Module																																																										
C	2012	Silverado	Body	Passenger Door Switch																																																										
C	2012	Silverado	Body	Passenger Presence System																																																										
C	2012	Silverado	Body	Radio																																																										
C	2012	Silverado	Body	Rear Heated Seat Module																																																										
C	2012	Silverado	Body	Rear HVAC/RSA																																																										
C	2012	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2012	Silverado	Body	Theft Deterrent Module																																																										
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2012	Silverado Hybrid	Body	Body Control Module																																																										
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2012	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2012	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2012	Silverado Hybrid	Body	HVAC Control Module																																																										
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2012	Silverado Hybrid	Body	Navigation Radio																																																										
C	2012	Silverado Hybrid	Body	Park Assist Module																																																										
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2012	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2012	Silverado Hybrid	Body	Radio																																																										
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																										
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Tahoe	Body	Amplifier (Bose)																																																										
C	2012	Tahoe	Body	Assist Step Controller																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2012	Tahoe	Body	Body Control Module																																																											
C	2012	Tahoe	Body	Body Control Module (aux.)																																																												
C	2012	Tahoe	Body	Digital Radio Receiver																																																												
C	2012	Tahoe	Body	Driver Door Switch																																																												
C	2012	Tahoe	Body	HVAC Control Module Auto																																																												
C	2012	Tahoe	Body	HVAC Control Module Manual																																																												
C	2012	Tahoe	Body	Instrument Panel Cluster																																																												
C	2012	Tahoe	Body	Left Side Object Detection Module																																																												
C	2012	Tahoe	Body	Lift Gate Module																																																												
C	2012	Tahoe	Body	Memory Seat Module																																																												
C	2012	Tahoe	Body	Navigation Radio																																																												
C	2012	Tahoe	Body	Park Assist Module																																																												
C	2012	Tahoe	Body	Passenger Door Switch																																																												
C	2012	Tahoe	Body	Passenger Presence System																																																												
C	2012	Tahoe	Body	Radio																																																												
C	2012	Tahoe	Body	Rear Heated Seat Module																																																												
C	2012	Tahoe	Body	Rear HVAC/RSA																																																												
C	2012	Tahoe	Body	Right Side Object Detection Module																																																												
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2012	Tahoe	Body	Theft Deterrent Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2012	Tahoe Hybrid	Body	Body Control Module																																																												
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																																												
C	2012	Tahoe Hybrid	Body	HVAC Control Module																																																												
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
C	2012	Tahoe Hybrid	Body	Lift Gate Module																																																												
C	2012	Tahoe Hybrid	Body	Navigation Radio																																																												
C	2012	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																												
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																																												
C	2012	Tahoe Hybrid	Body	Radio																																																												
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Avalanche	Body	Amplifier (Bose)																																																										
C	2013	Avalanche	Body	Assist Step Controller																																																										
C	2013	Avalanche	Body	Body Control Module																																																										
C	2013	Avalanche	Body	Body Control Module (aux.)																																																										
C	2013	Avalanche	Body	Digital Radio Receiver																																																										
C	2013	Avalanche	Body	Driver Door Switch																																																										
C	2013	Avalanche	Body	HVAC Control Module Auto																																																										
C	2013	Avalanche	Body	HVAC Control Module Manual																																																										
C	2013	Avalanche	Body	Instrument Panel Cluster																																																										
C	2013	Avalanche	Body	Memory Seat Module																																																										
C	2013	Avalanche	Body	Navigation Radio																																																										
C	2013	Avalanche	Body	Park Assist Module																																																										
C	2013	Avalanche	Body	Passenger Door Switch																																																										
C	2013	Avalanche	Body	Passenger Presence System																																																										
C	2013	Avalanche	Body	Radio																																																										
C	2013	Avalanche	Body	Rear Heated Seat Module																																																										
C	2013	Avalanche	Body	Rear HVAC/RSA																																																										
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2013	Avalanche	Body	Theft Deterrent Module																																																										
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2013	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2013	Captiva	Chassis	Parking Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																											
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																												
C	2013	Captiva	Body	Auxiliary Body Control Module																																																												
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2013	Captiva	Body	Instrument Cluster																																																												
C	2013	Captiva	Body	Headlamp Control Module																																																												
C	2013	Captiva	Body	HVAC Control Module																																																												
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																												
C	2013	Captiva	Body	Theft Deterrent Module																																																												
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																												
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
C	2013	Cheyenne	Body	Amplifier (Bose)																																																												
C	2013	Cheyenne	Body	Body Control Module																																																												
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																												
C	2013	Cheyenne	Body	Digital Radio Receiver																																																												
C	2013	Cheyenne	Body	Driver Door Switch																																																												
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																												
C	2013	Cheyenne	Body	Park Assist Module																																																												
C	2013	Cheyenne	Body	Passenger Door Switch																																																												
C	2013	Cheyenne	Body	Passenger Presence System																																																												
C	2013	Cheyenne	Body	Rear Heated Seat Module																																																												
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																												
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																												
C	2013	Cheyenne	Body	Theft Deterrent Module																																																												
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																												
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																												
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2013	Suburban	Chassis	Electronic Suspension Control																																																												
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Suburban	Body	Amplifier (Bose)																																																												
C	2013	Suburban	Body	Assist Step Controller																																																												
C	2013	Suburban	Body	Body Control Module																																																												
C	2013	Suburban	Body	Body Control Module (aux.)																																																												
C	2013	Suburban	Body	Digital Radio Receiver																																																												
C	2013	Suburban	Body	Driver Door Switch																																																												
C	2013	Suburban	Body	HVAC Control Module Auto																																																												
C	2013	Suburban	Body	HVAC Control Module Manual																																																												
C	2013	Suburban	Body	Instrument Panel Cluster																																																												
C	2013	Suburban	Body	Left Side Object Detection Module																																																												
C	2013	Suburban	Body	Lift Gate Module																																																												
C	2013	Suburban	Body	Memory Seat Module																																																												
C	2013	Suburban	Body	Navigation Radio																																																												
C	2013	Suburban	Body	Park Assist Module																																																												
C	2013	Suburban	Body	Passenger Door Switch																																																												
C	2013	Suburban	Body	Passenger Presence System																																																												
C	2013	Suburban	Body	Radio																																																												
C	2013	Suburban	Body	Rear Heated Seat Module																																																												
C	2013	Suburban	Body	Rear HVAC/RSA																																																												
C	2013	Suburban	Body	Right Side Object Detection Module																																																												
C	2013	Suburban	Body	Supplemental Inflatable Restraint																																																												
C	2013	Suburban	Body	Theft Deterrent Module																																																												
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																												
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																												
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2013	Silverado	Chassis	Electronic Suspension Control																																																												
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2013	Silverado	Body	Amplifier (Bose)																																																												
C	2013	Silverado	Body	Body Control Module																																																												
C	2013	Silverado	Body	Body Control Module (aux.)																																																												
C	2013	Silverado	Body	Digital Radio Receiver																																																												
C	2013	Silverado	Body	Driver Door Switch																																																												
C	2013	Silverado	Body	HVAC Control Module Auto																																																												
C	2013	Silverado	Body	HVAC Control Module Manual																																																												
C	2013	Silverado	Body	Instrument Panel Cluster																																																												
C	2013	Silverado	Body	Memory Seat Module																																																												
C	2013	Silverado	Body	Navigation Radio																																																												
C	2013	Silverado	Body	Park Assist Module																																																												
C	2013	Silverado	Body	Passenger Door Switch																																																												
C	2013	Silverado	Body	Passenger Presence System																																																												
C	2013	Silverado	Body	Radio																																																												
C	2013	Silverado	Body	Rear Heated Seat Module																																																												
C	2013	Silverado	Body	Rear HVAC/RSA																																																												
C	2013	Silverado	Body	Supplemental Inflatable Restraint																																																												
C	2013	Silverado	Body	Theft Deterrent Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																												
C	2013	Silverado Hybrid	Body	Body Control Module																																																												
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																												
C	2013	Silverado Hybrid	Body	Driver Door Switch																																																												
C	2013	Silverado Hybrid	Body	Heated Seat Module																																																												
C	2013	Silverado Hybrid	Body	HVAC Control Module																																																												
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
C	2013	Silverado Hybrid	Body	Navigation Radio																																																												
C	2013	Silverado Hybrid	Body	Park Assist Module																																																												
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																																												
C	2013	Silverado Hybrid	Body	Passenger Presence System																																																												
C	2013	Silverado Hybrid	Body	Radio																																																												
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																										
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Tahoe	Body	Amplifier (Bose)																																																										
C	2013	Tahoe	Body	Assist Step Controller																																																										
C	2013	Tahoe	Body	Body Control Module																																																										
C	2013	Tahoe	Body	Body Control Module (aux.)																																																										
C	2013	Tahoe	Body	Digital Radio Receiver																																																										
C	2013	Tahoe	Body	Driver Door Switch																																																										
C	2013	Tahoe	Body	HVAC Control Module Auto																																																										
C	2013	Tahoe	Body	HVAC Control Module Manual																																																										
C	2013	Tahoe	Body	Instrument Panel Cluster																																																										
C	2013	Tahoe	Body	Left Side Object Detection Module																																																										
C	2013	Tahoe	Body	Lift Gate Module																																																										
C	2013	Tahoe	Body	Memory Seat Module																																																										
C	2013	Tahoe	Body	Navigation Radio																																																										
C	2013	Tahoe	Body	Park Assist Module																																																										
C	2013	Tahoe	Body	Passenger Door Switch																																																										
C	2013	Tahoe	Body	Passenger Presence System																																																										
C	2013	Tahoe	Body	Radio																																																										
C	2013	Tahoe	Body	Rear Heated Seat Module																																																										
C	2013	Tahoe	Body	Rear HVAC/RSA																																																										
C	2013	Tahoe	Body	Right Side Object Detection Module																																																										
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2013	Tahoe	Body	Theft Deterrent Module																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2013	Tahoe Hybrid	Body	Body Control Module																																																										
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																																												
C	2013	Tahoe Hybrid	Body	HVAC Control Module																																																												
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
C	2013	Tahoe Hybrid	Body	Lift Gate Module																																																												
C	2013	Tahoe Hybrid	Body	Navigation Radio																																																												
C	2013	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																												
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																																												
C	2013	Tahoe Hybrid	Body	Radio																																																												
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																												
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																												
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																												
C	2014	Captiva (3GN)	Body	Body Control Module																																																												
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Captiva (3GN)	Body	Passenger Presence Module																																																												
C	2014	Captiva (3GN)	Body	Instrument Cluster																																																												
C	2014	Captiva (3GN)	Body	Radio																																																												
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																												
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Captiva (3GN)	Body	HVAC Control Module																																																												
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																				V																																								
C	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																												
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																												
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																												
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																												
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																												
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																										
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Captiva (Other)	Body	Instrument Cluster																																																										
C	2014	Captiva (Other)	Body	Headlamp Control Module																																																										
C	2014	Captiva (Other)	Body	HVAC Control Module																																																										
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
C	2014	Captiva (Other)	Body	Theft Deterrent Module																																																										
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																										
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																										
C	2014	Cheyenne	Chassis	Power Steering Control Module																																																										
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Cheyenne	Body	Body Control Module																																																										
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Cheyenne	Body	Passenger Presence Module																																																										
C	2014	Cheyenne	Body	Instrument Cluster																																																										
C	2014	Cheyenne	Body	Radio Control																																																										
C	2014	Cheyenne	Body	HVAC Control																																																										
C	2014	Cheyenne	Body	Radio																																																										
C	2014	Cheyenne	Body	Amplifier																																																										
C	2014	Cheyenne	Body	Media Disc Player																																																										
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																										
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
C	2014	Cheyenne	Body	HVAC Control Module																																																										
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																										
C	2014	Cheyenne	Body	Parking Assist Control Module																																																										
C	2014	Cheyenne	Body	Frontview Camera Module																																																										
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado	Chassis	Parking Brake Control Module																																																										
C	2014	Silverado	Chassis	Power Steering Control Module																																																										
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Silverado	Body	Body Control Module																																																										
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado	Body	Passenger Presence Module																																																										
C	2014	Silverado	Body	Instrument Cluster																																																										
C	2014	Silverado	Body	Radio Control																																																										
C	2014	Silverado	Body	HVAC Control																																																										
C	2014	Silverado	Body	Radio																																																										
C	2014	Silverado	Body	Amplifier																																																										
C	2014	Silverado	Body	Media Disc Player																																																										
C	2014	Silverado	Body	Human Machine Interface Control Module																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2014	Silverado	Body	Parking Assist Control Module																																																										
C	2014	Silverado	Body	Frontview Camera Module																																																										
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																										
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Suspension Control Module																																																										
C	2014	Silverado HD	Body	Body Control Module																																																										
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado HD	Body	Passenger Presence Module																																																										
C	2014	Silverado HD	Body	Instrument Cluster																																																										
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
C	2014	Silverado HD	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2014	Silverado HD	Body	Navigation Radio																																																										
C	2014	Silverado HD	Body	Uplevel Radio																																																										
C	2014	Silverado HD	Body	Amplifier																																																										
C	2014	Silverado HD	Body	Rear Audio Control Module																																																										
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																										
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																										
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																											V																															
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																											V																															
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																											V																															
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Silverado HD	Body	Seat Memory Control Module																																																										
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																										
C	2014	Silverado HD	Body	Parking Assist Control Module																				V																																						
C	2014	Silverado HD	Body	Theft Deterrent Module																																																										
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																										
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2014	Suburban	Chassis	Parking Brake Control Module																																																										
C	2014	Suburban	Chassis	Suspension Control Module																																																										
C	2014	Suburban	Body	Body Control Module																																																										
C	2014	Suburban	Body	Auxiliary Body Control Module																																																										
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Suburban	Body	Passenger Presence Module																																																										
C	2014	Suburban	Body	Instrument Cluster																																																										
C	2014	Suburban	Body	Base Radio																																																										
C	2014	Suburban	Body	Navigation Radio																																																										
C	2014	Suburban	Body	Uplevel Radio																																																										
C	2014	Suburban	Body	Amplifier																																																										
C	2014	Suburban	Body	Rear Audio Control Module																																																										
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																										
C	2014	Suburban	Body	Personal Audio Link Control Module																																																										
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																											V																															
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																											V																															
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Suburban	Body	Liftgate Control Module																																																										
C	2014	Suburban	Body	Seat Memory Control Module																																																										
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2014	Suburban	Body	Assist Step Control Module																																																										
C	2014	Suburban	Body	Right Side Object Detection Control Module																																																										
C	2014	Suburban	Body	Left Side Object Detection Control Module																																																										
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																										
C	2014	Suburban	Body	Parking Assist Control Module																				V																																						
C	2014	Suburban	Body	Theft Deterrent Module																																																										
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																										
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																										
C	2014	Tahoe	Chassis	Suspension Control Module																																																										
C	2014	Tahoe	Body	Body Control Module																																																										
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																										
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Tahoe	Body	Passenger Presence Module																																																										
C	2014	Tahoe	Body	Instrument Cluster																																																										
C	2014	Tahoe	Body	Base Radio																																																										
C	2014	Tahoe	Body	Navigation Radio																																																										
C	2014	Tahoe	Body	Uplevel Radio																																																										
C	2014	Tahoe	Body	Amplifier																																																										
C	2014	Tahoe	Body	Rear Audio Control Module																																																										
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																										
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																										
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																											V																															
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																											V																															
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Tahoe	Body	Liftgate Control Module																																																										
C	2014	Tahoe	Body	Seat Memory Control Module																																																										
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																																										
C	2014	Tahoe	Body	Assist Step Control Module																																																										
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																																										
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																																										
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																										
C	2014	Tahoe	Body	Parking Assist Control Module																				V																																						
C	2014	Tahoe	Body	Theft Deterrent Module																																																										
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2015	Captiva (3GN)	Body	Body Control Module																																																										
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																																										
C	2015	Captiva (3GN)	Body	Instrument Cluster																																																										
C	2015	Captiva (3GN)	Body	Radio																																																										
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
C	2015	Captiva (3GN)	Body	HVAC Control Module																																																										
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																				V																																						
C	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																										
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																										
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Captiva (Other)	Body	Instrument Cluster																																																										
C	2015	Captiva (Other)	Body	Headlamp Control Module																																																										
C	2015	Captiva (Other)	Body	HVAC Control Module																																																										
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
C	2015	Captiva (Other)	Body	Theft Deterrent Module																																																										
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																										
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																												
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																													
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																													
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																													
C	2015	Cheyenne	Chassis	Power Steering Control Module																																																													
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2015	Cheyenne	Chassis	Suspension Control Module																																																													
C	2015	Cheyenne	Body	Body Control Module																																																													
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2015	Cheyenne	Body	Passenger Presence Module																																																													
C	2015	Cheyenne	Body	Instrument Cluster																																																													
C	2015	Cheyenne	Body	Radio Controls																																																													
C	2015	Cheyenne	Body	HVAC Controls																																																													
C	2015	Cheyenne	Body	Radio																																																													
C	2015	Cheyenne	Body	Amplifier																																																													
C	2015	Cheyenne	Body	Media Disc Player																																																													
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																													
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																													
C	2015	Cheyenne	Body	HVAC Control Module																																																													
C	2015	Cheyenne	Body	Parking Assist Control Module																																																													
C	2015	Cheyenne	Body	Frontview Camera Module																																																													
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																														
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																														
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																														
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																														
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																														
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																														
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
C	2015	Silverado	Chassis	Electronic Brake Control Module																																																														
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																														
C	2015	Silverado	Chassis	Power Steering Control Module																																																														

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Silverado	Chassis	Suspension Control Module																																																												
C	2015	Silverado	Body	Body Control Module																																																											
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Silverado	Body	Passenger Presence Module																																																											
C	2015	Silverado	Body	Instrument Cluster																																																											
C	2015	Silverado	Body	Radio Controls																																																										
C	2015	Silverado	Body	HVAC Controls																																																										
C	2015	Silverado	Body	Radio																																																										
C	2015	Silverado	Body	Amplifier																																																										
C	2015	Silverado	Body	Media Disc Player																																																										
C	2015	Silverado	Body	Human Machine Interface Control Module																																																										
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																										
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2015	Silverado	Body	Parking Assist Control Module																																																										
C	2015	Silverado	Body	Frontview Camera Module																																																										
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Suburban	Chassis	Parking Brake Control Module																																																										
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Suburban	Chassis	Power Steering Control Module																																																										
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Suburban	Chassis	Suspension Control Module																																																										
C	2015	Suburban	Body	Body Control Module																																																										
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Suburban	Body	Passenger Presence Module																																																										
C	2015	Suburban	Body	Instrument Cluster																																																										
C	2015	Suburban	Body	Radio Controls																																																										
C	2015	Suburban	Body	HVAC Controls																																																										
C	2015	Suburban	Body	Radio																																																										
C	2015	Suburban	Body	Amplifier																																																										
C	2015	Suburban	Body	Media Disc Player																																																										
C	2015	Suburban	Body	Human Machine Interface Control Module																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Suburban	Body	HVAC Control Module																																																										
C	2015	Suburban	Body	Liftgate Control Module																																																										
C	2015	Suburban	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2015	Suburban	Body	Assist Step Control Module																																																										
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																										
C	2015	Suburban	Body	Parking Assist Control Module																																																										
C	2015	Suburban	Body	Frontview Camera Module																																																										
C	2015	Suburban	Body	Steering Column Lock Control Module																																																										
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																										
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																										
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																										
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Tahoe	Chassis	Power Steering Control Module																																																										
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Tahoe	Chassis	Suspension Control Module																																																										
C	2015	Tahoe	Body	Body Control Module																																																										
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Tahoe	Body	Passenger Presence Module																																																										
C	2015	Tahoe	Body	Instrument Cluster																																																										
C	2015	Tahoe	Body	Radio Controls																																																										
C	2015	Tahoe	Body	HVAC Controls																																																										
C	2015	Tahoe	Body	Radio																																																										
C	2015	Tahoe	Body	Amplifier																																																										
C	2015	Tahoe	Body	Media Disc Player																																																										
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																										
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																										
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Tahoe	Body	HVAC Control Module																																																										
C	2015	Tahoe	Body	Liftgate Control Module																																																										
C	2015	Tahoe	Body	Keyless Entry Control Module																																																										
C	2015	Tahoe	Body	Assist Step Control Module																																																										
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																										
C	2015	Tahoe	Body	Parking Assist Control Module																																																										
C	2015	Tahoe	Body	Frontview Camera Module																																																										
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																										
C	2015	Tahoe	Body	Battery Energy Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
C	2016	Captiva (3GN)	Body	Body Control Module																																																										
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																										
C	2016	Captiva (3GN)	Body	Radio																																																										
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																										
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																										
C	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																										
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																										
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Captiva (Other)	Body	Instrument Cluster																																																										
C	2016	Captiva (Other)	Body	Headlamp Control Module																																																										
C	2016	Captiva (Other)	Body	Radio																																																										
C	2016	Captiva (Other)	Body	HVAC Control Module																																																										
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																										
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																										
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
C	2016	Captiva (Other)	Body	Theft Deterrent Module																																																										
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																												
C	2016	Cheyenne	Chassis	Power Steering Control Module																																																												
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2016	Cheyenne	Chassis	Suspension Control Module																																																												
C	2016	Cheyenne	Body	Body Control Module																																																												
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Cheyenne	Body	Passenger Presence Module																																																												
C	2016	Cheyenne	Body	Instrument Cluster																																																												
C	2016	Cheyenne	Body	Radio Controls																																																												
C	2016	Cheyenne	Body	HVAC Controls																																																												
C	2016	Cheyenne	Body	Radio																																																												
C	2016	Cheyenne	Body	Amplifier																																																												
C	2016	Cheyenne	Body	Media Disc Player																																																												
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																												
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																												
C	2016	Cheyenne	Body	HVAC Control Module																																																												
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																												
C	2016	Cheyenne	Body	Parking Assist Control Module																																																												
C	2016	Cheyenne	Body	Frontview Camera Module																																																												
C	2016	Cheyenne	Body	Frontview Camera Module																																																												
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																												
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																												
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																												
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																												
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																												
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																												
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																												
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2016	Silverado	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2016	Silverado	Chassis	Power Steering Control Module																																																											
C	2016	Silverado	Chassis	Power Steering Control Module																																																												
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2016	Silverado	Chassis	Suspension Control Module																																																												
C	2016	Silverado	Body	Body Control Module																																																												
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Silverado	Body	Passenger Presence Module																																																												
C	2016	Silverado	Body	Instrument Cluster																																																												
C	2016	Silverado	Body	Radio Controls																																																												
C	2016	Silverado	Body	HVAC Controls																																																												
C	2016	Silverado	Body	Radio (IO3)																																																												
C	2016	Silverado	Body	Radio (IOB)																																																												
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																												
C	2016	Silverado	Body	Amplifier																																																												
C	2016	Silverado	Body	Media Disc Player																																																												
C	2016	Silverado	Body	Human Machine Interface Control Module																																																												
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																												
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																												
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																												
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																												
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																												
C	2016	Silverado	Body	Parking Assist Control Module																																																												
C	2016	Silverado	Body	Frontview Camera Module																																																												
C	2016	Silverado	Body	Frontview Camera Module																																																												
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2016	Suburban	Chassis	Electronic Brake Control Module																																																												
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																												
C	2016	Suburban	Chassis	Parking Brake Control Module																																																												
C	2016	Suburban	Chassis	Power Steering Control Module																																																												
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2016	Suburban	Chassis	Suspension Control Module																																																												
C	2016	Suburban	Body	Body Control Module																																																												
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Suburban	Body	Passenger Presence Module																																																												
C	2016	Suburban	Body	Instrument Cluster																																																												
C	2016	Suburban	Body	Radio Controls																																																												
C	2016	Suburban	Body	HVAC Controls																																																												
C	2016	Suburban	Body	Radio																																																												
C	2016	Suburban	Body	Amplifier																																																												
C	2016	Suburban	Body	Media Disc Player																																																												
C	2016	Suburban	Body	Human Machine Interface Control Module																																																												
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																																												
C	2016	Suburban	Body	HVAC Control Module																																																												
C	2016	Suburban	Body	Liftgate Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																										
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																										
C	2016	Suburban	Body	Keyless Entry Control Module																																																										
C	2016	Suburban	Body	Assist Step Control Module																																																										
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																										
C	2016	Suburban	Body	Parking Assist Control Module																																																										
C	2016	Suburban	Body	Frontview Camera Module																																																										
C	2016	Suburban	Body	Steering Column Lock Control Module																																																										
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																										
C	2016	Tahoe	Chassis	Power Steering Control Module																																																										
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Tahoe	Chassis	Suspension Control Module																																																										
C	2016	Tahoe	Body	Body Control Module																																																										
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Tahoe	Body	Passenger Presence Module																																																										
C	2016	Tahoe	Body	Instrument Cluster																																																										
C	2016	Tahoe	Body	Radio Controls																																																										
C	2016	Tahoe	Body	HVAC Controls																																																										
C	2016	Tahoe	Body	Radio																																																										
C	2016	Tahoe	Body	Amplifier																																																										
C	2016	Tahoe	Body	Media Disc Player																																																										
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																										
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																										
C	2016	Tahoe	Body	HVAC Control Module																																																										
C	2016	Tahoe	Body	Liftgate Control Module																																																										
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																										
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																										
C	2016	Tahoe	Body	Keyless Entry Control Module																																																										
C	2016	Tahoe	Body	Assist Step Control Module																																																										
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																										
C	2016	Tahoe	Body	Parking Assist Control Module																																																										
C	2016	Tahoe	Body	Frontview Camera Module																																																										
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																										
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																										
E	2004	ALL	Chassis	Electronic Brake Control Module																																																										
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2006	ALL	Chassis	Electronic Brake Control Module																																																										
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2007	ALL	Chassis	Electronic Brake Control Module																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																										
G	2004	Express/Savana	Body	Body Control Module																																																										
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2004	Express/Savana	Body	OnStar																																																										
G	2004	Express/Savana	Body	Base Radio																																																										
G	2004	Express/Savana	Body	Uplevel Radio																																																										
G	2004	Express/Savana	Body	Remote Function Actuation																																																										
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																													V	V												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																													V	V												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																																										
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2005	Express/Savana	Chassis	VSES																																																										
G	2005	Express/Savana	Body	Body Control Module																																																										
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2005	Express/Savana	Body	Base Radio																																																										
G	2005	Express/Savana	Body	Uplevel Radio																																																										
G	2005	Express/Savana	Body	Remote Function Actuation																																																										
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2005	Express Access/Savana Pro	Chassis	VSES																																																										
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2005	Express Access/Savana Pro	Body	Base Radio																																																										
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2006	Express/Savana	Chassis	VSES																																																										
G	2006	Express/Savana	Body	Body Control Module																																																										
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2006	Express/Savana	Body	Passenger Presence System																																																										
G	2006	Express/Savana	Body	Base Radio																																																										
G	2006	Express/Savana	Body	Uplevel Radio																																																										
G	2006	Express/Savana	Body	Remote Function Actuation																																																										
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2006	Express Access/Savana Pro	Chassis	VSES																																																										
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2006	Express Access/Savana Pro	Body	Base Radio																																																										
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																													
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																													
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																													
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																													
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																													
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																													
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																													
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																													
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																													
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																													
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																													
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																													
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																													
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																													
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																													
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																													
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																													
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																													
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2007	Express/Savana	Body	Body Control Module																																																													
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																													
G	2007	Express/Savana	Body	Passenger Presence System																																																													
G	2007	Express/Savana	Body	Base Radio																																																													
G	2007	Express/Savana	Body	Uplevel Radio																																																													
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																													
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																													
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																													
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																													
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																													
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																													
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																													
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																													
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																													
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																													
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																													
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																													
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																													
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2007	Express Access/Savana Pro	Body	Radio																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express/Savana	Body	Body Control Module																																																										
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2008	Express/Savana	Body	Passenger Presence System																																																										
G	2008	Express/Savana	Body	Radio																																																										
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express/Savana	Body	Rollover Sensor																																																										
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2008	Express/Savana	Body	Theft Deterrent Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES
G	2008	Express Access/Savana Pro	Body	Body Control Module
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster
G	2008	Express Access/Savana Pro	Body	Passenger Presence System
G	2008	Express Access/Savana Pro	Body	Radio
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver
G	2008	Express Access/Savana Pro	Body	Rollover Sensor
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES
G	2009	Express/Savana	Body	Body Control Module
G	2009	Express/Savana	Body	Instrument Panel Cluster
G	2009	Express/Savana	Body	Passenger Presence System
G	2009	Express/Savana	Body	Radio
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver
G	2009	Express/Savana	Body	Rollover Sensor
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint
G	2009	Express/Savana	Body	Theft Deterrent Module
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2009	Express Access/Savana Pro	Body	Radio																																																												
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express/Savana	Body	Body Control Module																																																												
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2010	Express/Savana	Body	Passenger Presence System																																																												
G	2010	Express/Savana	Body	Radio																																																											
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2010	Express/Savana	Body	Rollover Sensor																																																											
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2010	Express/Savana	Body	Theft Deterrent Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2010	Express Access/Savana Pro	Body	Radio																																																												
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2011	Express/Savana	Body	Body Control Module																																																												
G	2011	Express/Savana	Body	Digital Radio Receiver																																																												
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2011	Express/Savana	Body	Passenger Presence System																																																												
G	2011	Express/Savana	Body	Radio																																																											
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2011	Express/Savana	Body	Rollover Sensor																																																												
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2011	Express/Savana	Body	Theft Deterrent Module																																																												
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2011	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2011	Express Access/Savana Pro	Body	Radio																																																										
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2012	Express/Savana	Body	Body Control Module																																																										
G	2012	Express/Savana	Body	Digital Radio Receiver																																																										
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2012	Express/Savana	Body	Passenger Presence System																																																										
G	2012	Express/Savana	Body	Radio																																																										
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2012	Express/Savana	Body	Rollover Sensor																																																										
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2012	Express/Savana	Body	Theft Deterrent Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2012	Express Access/Savana Pro	Body	Radio																																																										
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2013	Express/Savana	Body	Body Control Module																																																										
G	2013	Express/Savana	Body	Digital Radio Receiver																																																										
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2013	Express/Savana	Body	Navigation Radio																																																										
G	2013	Express/Savana	Body	Park Assist Module																																																										
G	2013	Express/Savana	Body	Passenger Presence System																																																										
G	2013	Express/Savana	Body	Radio																																																										
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2013	Express/Savana	Body	Rollover Sensor																																																										
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2013	Express/Savana	Body	Theft Deterrent Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2013	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2013	Express Access/Savana Pro	Body	Radio																																																										
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2014	Express	Chassis	Electronic Brake Control Module																																																										
G	2014	Express	Body	Body Control Module																																																										
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2014	Express	Body	Passenger Presence Module																																																										
G	2014	Express	Body	Rollover Sensor Module																																																										
G	2014	Express	Body	Instrument Cluster																																																										
G	2014	Express	Body	Chime Alarm Control Module																																																										
G	2014	Express	Body	Base Radio																																																										
G	2014	Express	Body	Navigation Radio																																																										
G	2014	Express	Body	Uplevel Radio																																																										
G	2014	Express	Body	Digital Radio Receiver Control Module																																																										
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2014	Express	Body	Auxiliary Heater Control Module																																																										
G	2014	Express	Body	Remote Control Door Lock Receiver																																																										
G	2014	Express	Body	Parking Assist Control Module																																																										
G	2014	Express	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2014	Savana	Chassis	Electronic Brake Control Module																																																										
G	2014	Savana	Body	Body Control Module																																																										
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2014	Savana	Body	Passenger Presence Module																																																										
G	2014	Savana	Body	Rollover Sensor Module																																																										
G	2014	Savana	Body	Instrument Cluster																																																										
G	2014	Savana	Body	Chime Alarm Control Module																																																										
G	2014	Savana	Body	Base Radio																																																										
G	2014	Savana	Body	Navigation Radio																																																										
G	2014	Savana	Body	Uplevel Radio																																																										
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2014	Savana	Body	Auxiliary Heater Control Module																																																										
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
G	2014	Savana	Body	Parking Assist Control Module																																																										
G	2014	Savana	Body	Theft Deterrent Module																																																										
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2015	Express	Chassis	Electronic Brake Control Module																																																										
G	2015	Express	Body	Body Control Module																																																										
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2015	Express	Body	Rollover Sensor Module																																																										
G	2015	Express	Body	Instrument Cluster																																																										
G	2015	Express	Body	Digital Radio Receiver Control Module																																																										
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2015	Express	Body	Auxiliary Heater Control Module																																																										
G	2015	Express	Body	Remote Control Door Lock Receiver																																																										
G	2015	Express	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2015	Express	Body	Theft Deterrent Module																																																											
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
G	2015	Savana	Chassis	Electronic Brake Control Module																																																												
G	2015	Savana	Body	Body Control Module																																																											
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
G	2015	Savana	Body	Rollover Sensor Module																																																											
G	2015	Savana	Body	Instrument Cluster																																																											
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																											
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											
G	2015	Savana	Body	Auxiliary Heater Control Module																																																											
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																											
G	2015	Savana	Body	Parking Assist Control Module																																																											
G	2015	Savana	Body	Theft Deterrent Module																																																											
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
G	2016	Express	Chassis	Electronic Brake Control Module																																																											
G	2016	Express	Body	Body Control Module																																																										
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
G	2016	Express	Body	Instrument Cluster																																																										
G	2016	Express	Body	Chime Alarm Control Module																																																										
G	2016	Express	Body	Base Radio																																																										
G	2016	Express	Body	Navigation Radio																																																										
G	2016	Express	Body	Uplevel Radio																																																										
G	2016	Express	Body	Digital Radio Receiver Control Module																																																											
G	2016	Express	Body	Telematics Communication Interface Control Module																																																											
G	2016	Express	Body	Auxiliary Heater Control Module																																																											
G	2016	Express	Body	Remote Control Door Lock Receiver																																																											
G	2016	Express	Body	Parking Assist Control Module																																																											
G	2016	Express	Body	Theft Deterrent Module																																																											
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2016	Savana	Chassis	Electronic Brake Control Module																																																										
G	2016	Savana	Body	Body Control Module																																																										
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2016	Savana	Body	Instrument Cluster																																																										
G	2016	Savana	Body	Chime Alarm Control Module																																																										
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
G	2016	Savana	Body	Auxiliary Heater Control Module																																																										
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
G	2016	Savana	Body	Parking Assist Control Module																																																										
G	2016	Savana	Body	Theft Deterrent Module																																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2004	Express/Savana	Chassis	VSES																																																										
H	2004	Express/Savana	Body	Body Control Module																																																										
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2004	Express/Savana	Body	OnStar																																																										
H	2004	Express/Savana	Body	Base Radio																																																										
H	2004	Express/Savana	Body	Uplevel Radio																																																										
H	2004	Express/Savana	Body	Remote Function Actuation																																																										
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2004	Express Access/Savana Pro	Chassis	VSES																																																										
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2004	Express Access/Savana Pro	Body	OnStar																																																										
H	2004	Express Access/Savana Pro	Body	Base Radio																																																										
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2005	Express/Savana	Chassis	VSES																																																										
H	2005	Express/Savana	Body	Body Control Module																																																										
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2005	Express/Savana	Body	Base Radio																																																										
H	2005	Express/Savana	Body	Uplevel Radio																																																										
H	2005	Express/Savana	Body	Remote Function Actuation																																																										
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2005	Express Access/Savana Pro	Chassis	VSES																																																										
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2005	Express Access/Savana Pro	Body	Base Radio																																																										
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2006	Express/Savana	Chassis	VSES																																																										
H	2006	Express/Savana	Body	Body Control Module																																																										
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2006	Express/Savana	Body	Passenger Presence System																																																										
H	2006	Express/Savana	Body	Base Radio																																																										
H	2006	Express/Savana	Body	Uplevel Radio																																																										
H	2006	Express/Savana	Body	Remote Function Actuation																																																										
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2006	Express Access/Savana Pro	Chassis	VSES																																																										
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2006	Express Access/Savana Pro	Body	Base Radio																																																										
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2007	Express/Savana	Body	Body Control Module																																																												
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																												
H	2007	Express/Savana	Body	Passenger Presence System																																																												
H	2007	Express/Savana	Body	Base Radio																																																												
H	2007	Express/Savana	Body	Uplevel Radio																																																												
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2007	Express Access/Savana Pro	Body	Base Radio																																																												
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2008	Express/Savana	Body	Body Control Module																																																												
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2008	Express/Savana	Body	Passenger Presence System																																																												
H	2008	Express/Savana	Body	Radio																																																											
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
H	2008	Express/Savana	Body	Rollover Sensor																																																											
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2008	Express/Savana	Body	Theft Deterrent Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module																																																										
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																																										
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express/Savana	Body	Theft Deterrent Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express/Savana	Body	Body Control Module																																																										
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2010	Express/Savana	Body	Passenger Presence System																																																										
H	2010	Express/Savana	Body	Radio																																																										
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express/Savana	Body	Rollover Sensor																																																										
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express/Savana	Body	Theft Deterrent Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2010	Express Access/Savana Pro	Body	Radio																																																										
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2011	Express/Savana	Body	Body Control Module																																																										
H	2011	Express/Savana	Body	Digital Radio Receiver																																																										
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2011	Express/Savana	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2011	Express/Savana	Body	Radio																																																										
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2011	Express/Savana	Body	Rollover Sensor																																																										
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2011	Express/Savana	Body	Theft Deterrent Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2011	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2011	Express Access/Savana Pro	Body	Radio																																																										
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2012	Express/Savana	Body	Body Control Module																																																										
H	2012	Express/Savana	Body	Digital Radio Receiver																																																										
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2012	Express/Savana	Body	Passenger Presence System																																																										
H	2012	Express/Savana	Body	Radio																																																										
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2012	Express/Savana	Body	Rollover Sensor																																																										
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2012	Express/Savana	Body	Theft Deterrent Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES
H	2012	Express Access/Savana Pro	Body	Body Control Module
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster
H	2012	Express Access/Savana Pro	Body	Passenger Presence System
H	2012	Express Access/Savana Pro	Body	Radio
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver
H	2012	Express Access/Savana Pro	Body	Rollover Sensor
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES
H	2013	Express/Savana	Body	Body Control Module
H	2013	Express/Savana	Body	Digital Radio Receiver
H	2013	Express/Savana	Body	Instrument Panel Cluster
H	2013	Express/Savana	Body	Navigation Radio
H	2013	Express/Savana	Body	Park Assist Module
H	2013	Express/Savana	Body	Passenger Presence System
H	2013	Express/Savana	Body	Radio
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver
H	2013	Express/Savana	Body	Rollover Sensor
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint
H	2013	Express/Savana	Body	Theft Deterrent Module
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES
H	2013	Express Access/Savana Pro	Body	Body Control Module
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster
H	2013	Express Access/Savana Pro	Body	Navigation Radio

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2013	Express Access/Savana Pro	Body	Radio																																																										
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2014	Express	Chassis	Electronic Brake Control Module																																																										
H	2014	Express	Body	Body Control Module																																																										
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Express	Body	Passenger Presence Module																																																										
H	2014	Express	Body	Rollover Sensor Module																																																										
H	2014	Express	Body	Instrument Cluster																																																										
H	2014	Express	Body	Chime Alarm Control Module																																																										
H	2014	Express	Body	Base Radio																																																										
H	2014	Express	Body	Navigation Radio																																																										
H	2014	Express	Body	Uplevel Radio																																																										
H	2014	Express	Body	Digital Radio Receiver Control Module																																																										
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2014	Express	Body	Auxiliary Heater Control Module																																																										
H	2014	Express	Body	Remote Control Door Lock Receiver																																																										
H	2014	Express	Body	Parking Assist Control Module																																																										
H	2014	Express	Body	Theft Deterrent Module																																																										
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
H	2014	Savana	Chassis	Electronic Brake Control Module																																																												
H	2014	Savana	Body	Body Control Module																																																											
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2014	Savana	Body	Passenger Presence Module																																																											
H	2014	Savana	Body	Rollover Sensor Module																																																											
H	2014	Savana	Body	Instrument Cluster																																																											
H	2014	Savana	Body	Chime Alarm Control Module																																																											
H	2014	Savana	Body	Base Radio																																																											
H	2014	Savana	Body	Navigation Radio																																																											
H	2014	Savana	Body	Uplevel Radio																																																											
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																											
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											
H	2014	Savana	Body	Auxiliary Heater Control Module																																																											
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																											
H	2014	Savana	Body	Parking Assist Control Module																																																											
H	2014	Savana	Body	Theft Deterrent Module																																																											
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
H	2015	Express	Chassis	Electronic Brake Control Module																																																											
H	2015	Express	Body	Body Control Module																																																											
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2015	Express	Body	Rollover Sensor Module																																																											
H	2015	Express	Body	Instrument Cluster																																																											
H	2015	Express	Body	Digital Radio Receiver Control Module																																																											
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																											
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																											
H	2015	Express	Body	Auxiliary Heater Control Module																																																											
H	2015	Express	Body	Remote Control Door Lock Receiver																																																											
H	2015	Express	Body	Parking Assist Control Module																																																											
H	2015	Express	Body	Theft Deterrent Module																																																											
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
H	2015	Savana	Chassis	Electronic Brake Control Module																																																											
H	2015	Savana	Body	Body Control Module																																																											
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2015	Savana	Body	Rollover Sensor Module																																																											
H	2015	Savana	Body	Instrument Cluster																																																												
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																												
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																												
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																												
H	2015	Savana	Body	Auxiliary Heater Control Module																																																												
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																												
H	2015	Savana	Body	Parking Assist Control Module																																																												
H	2015	Savana	Body	Theft Deterrent Module																																																												
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
H	2016	Express	Chassis	Electronic Brake Control Module																																																												
H	2016	Express	Body	Body Control Module																																																											
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2016	Express	Body	Instrument Cluster																																																												
H	2016	Express	Body	Chime Alarm Control Module																																																												
H	2016	Express	Body	Base Radio																																																											
H	2016	Express	Body	Navigation Radio																																																											
H	2016	Express	Body	Uplevel Radio																																																											
H	2016	Express	Body	Digital Radio Receiver Control Module																																																												
H	2016	Express	Body	Telematics Communication Interface Control Module																																																												
H	2016	Express	Body	Auxiliary Heater Control Module																																																												
H	2016	Express	Body	Remote Control Door Lock Receiver																																																												
H	2016	Express	Body	Parking Assist Control Module																																																												
H	2016	Express	Body	Theft Deterrent Module																																																												
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
H	2016	Savana	Chassis	Electronic Brake Control Module																																																												
H	2016	Savana	Body	Body Control Module																																																											
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2016	Savana	Body	Instrument Cluster																																																												
H	2016	Savana	Body	Chime Alarm Control Module																																																												
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																												
H	2016	Savana	Body	Telematics Communication Interface Control Module																																																												
H	2016	Savana	Body	Auxiliary Heater Control Module																																																												
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																												
H	2016	Savana	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2016	Savana	Body	Theft Deterrent Module																																																										
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																										
J	2004	ALL	Chassis	Electronic Brake Control Module																																																										
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
J	2007	ALL	Chassis	Electronic Brake Control Module																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																										
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Tracker	Chassis	Power Steering Control Module																																																										
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Tracker	Body	Body Control Module																																																										
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Tracker	Body	Passenger Presence Module																																																										
J	2013	Tracker	Body	Instrument Cluster																																																										
J	2013	Tracker	Body	Radio																																																										
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																																										
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Tracker	Body	Front Seat Heating Control Module																																																										
J	2013	Tracker	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2013	Tracker	Body	Frontview Camera Module																					V																																							
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																												
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
J	2013	Trax	Chassis	Electronic Brake Control Module																																																												
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2013	Trax	Chassis	Power Steering Control Module																																																												
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2013	Trax	Body	Body Control Module																																																												
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2013	Trax	Body	Passenger Presence Module																																																												
J	2013	Trax	Body	Instrument Cluster																																																												
J	2013	Trax	Body	Radio																																																											
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
J	2013	Trax	Body	Front Seat Heating Control Module																																																												
J	2013	Trax	Body	Parking Assist Control Module																																																												
J	2013	Trax	Body	Frontview Camera Module																					V																																							
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																											
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																											
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																											
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																											
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																											
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																																											
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																											
J	2014	Tracker	Chassis	Power Steering Control Module																																																											
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2014	Tracker	Body	Body Control Module																																																											
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2014	Tracker	Body	Passenger Presence Module																																																											
J	2014	Tracker	Body	Instrument Cluster																																																											
J	2014	Tracker	Body	Radio																																																										
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																																											
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																																											
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																																											
J	2014	Tracker	Body	Front Seat Heating Control Module																																																											
J	2014	Tracker	Body	Parking Assist Control Module																																																											
J	2014	Tracker	Body	Frontview Camera Module																					V																																							
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2014	Trax	Chassis	Electronic Brake Control Module																																																										
J	2014	Trax	Chassis	Power Steering Control Module																																																										
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Trax	Body	Body Control Module																																																										
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Trax	Body	Passenger Presence Module																																																										
J	2014	Trax	Body	Instrument Cluster																																																										
J	2014	Trax	Body	Radio																																																										
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Trax	Body	Front Seat Heating Control Module																																																										
J	2014	Trax	Body	Parking Assist Control Module																																																										
J	2014	Trax	Body	Frontview Camera Module																					V																																					
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2015	Tracker	Chassis	Power Steering Control Module																																																										
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Tracker	Body	Body Control Module																																																										
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Tracker	Body	Instrument Cluster																																																										
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																																										
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Tracker	Body	Front Seat Heating Control Module																																																										
J	2015	Tracker	Body	Parking Assist Control Module																				V																																						
J	2015	Tracker	Body	Frontview Camera Module																					V																																					
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2015	Trax	Powertrain	Chassis Control Module																																																										
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Trax	Chassis	Electronic Brake Control Module																																																										
J	2015	Trax	Chassis	Power Steering Control Module																																																										
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Trax	Body	Body Control Module																																																										
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Trax	Body	Passenger Presence Module																																																										
J	2015	Trax	Body	Instrument Cluster																																																										
J	2015	Trax	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Trax	Body	Seat Memory Control Module																																																										
J	2015	Trax	Body	Front Seat Heating Control Module																																																										
J	2015	Trax	Body	Right Side Object Detection Control Module																																																										
J	2015	Trax	Body	Left Side Object Detection Control Module																																																										
J	2015	Trax	Body	Parking Assist Control Module																					V																																					
J	2015	Trax	Body	Frontview Camera Module																						V																																				
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																										
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2016	Tracker	Chassis	Power Steering Control Module																																																										
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Tracker	Body	Body Control Module																																																										
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Tracker	Body	Instrument Cluster																																																										
J	2016	Tracker	Body	Trailer Interface Control Module																																																										
J	2016	Tracker	Body	Radio																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Tracker	Body	Front Seat Heating Control Module																																																										
J	2016	Tracker	Body	Parking Assist Control Module																																																										
J	2016	Tracker	Body	Frontview Camera Module																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2016	Trax	Powertrain	Chassis Control Module																																																										
J	2016	Trax	Chassis	Electronic Brake Control Module																																																										
J	2016	Trax	Chassis	Power Steering Control Module																																																										
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Trax	Body	Body Control Module																																																										
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Trax	Body	Passenger Presence Module																																																										
J	2016	Trax	Body	Instrument Cluster																																																										
J	2016	Trax	Body	Trailer Interface Control Module																																																										
J	2016	Trax	Body	Radio																																																										
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Trax	Body	Seat Memory Control Module																																																										
J	2016	Trax	Body	Front Seat Heating Control Module																																																										
J	2016	Trax	Body	Right Side Object Detection Control Module																																																										
J	2016	Trax	Body	Left Side Object Detection Control Module																																																										
J	2016	Trax	Body	Parking Assist Control Module																																																										
J	2016	Trax	Body	Frontview Camera Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
K	2004	ALL	Chassis	ESC																																																											
K	2004	ALL	Chassis	Rear Wheel Steering																																																												
K	2004	ALL	Chassis	Tire Pressure Monitor																																																												
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																												
K	2004	ALL	Chassis	VSES																																																											
K	2004	ALL	Body	Amplifier (Bose)																																																												
K	2004	ALL	Body	Body Control Module																																																												
K	2004	ALL	Body	CD Changer																																																												
K	2004	ALL	Body	Chime																																																												
K	2004	ALL	Body	Driver Door Module																																																												
K	2004	ALL	Body	Driver Seat Module																																																												
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2004	ALL	Body	Instrument Panel Cluster																																																												
K	2004	ALL	Body	OnStar																																																											
K	2004	ALL	Body	Passenger Door Module																																																												
K	2004	ALL	Body	Passenger Presence System																																																												
K	2004	ALL	Body	Radio Base																																																												
K	2004	ALL	Body	Radio Uplevel																																																												
K	2004	ALL	Body	Radio Navigation																																																												
K	2004	ALL	Body	Rear Aux. Climate Module																																																												
K	2004	ALL	Body	Rear HVAC																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2004	ALL	Body	Rear Seat Audio																																																										
K	2004	ALL	Body	Rear Seat Entertainment																																																										
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2004	ALL	Body	Vehicle Theft Deterrent																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2005	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
K	2006	ALL	Chassis	ESC																																																											
K	2006	ALL	Chassis	Tire Pressure Monitor																																																											
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																											
K	2006	ALL	Chassis	VSES																																																										
K	2006	ALL	Body	Amplifier (Bose)																																																											
K	2006	ALL	Body	Body Control Module																																																										
K	2006	ALL	Body	CD Changer																																																										
K	2006	ALL	Body	Chime																																																										
K	2006	ALL	Body	Disc Player and Video Display																																																										
K	2006	ALL	Body	Driver Door Module																																																										
K	2006	ALL	Body	Driver Seat Module																																																										
K	2006	ALL	Body	Generator Battery Control Module																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2006	ALL	Body	Instrument Panel Cluster																																																											
K	2006	ALL	Body	Passenger Door Module																																																											
K	2006	ALL	Body	Passenger Presence System																																																											
K	2006	ALL	Body	Base Radio																																																											
K	2006	ALL	Body	Uplevel Radio																																																											
K	2006	ALL	Body	Navigation Radio																																																											
K	2006	ALL	Body	Rear Aux. Climate Module																																																											
K	2006	ALL	Body	Rear HVAC																																																											
K	2006	ALL	Body	Rear Seat Audio																																																											
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2006	ALL	Body	Vehicle Theft Deterrent																																																											
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																											
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2007	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																																											
K	2007	Avalanche	Body	Amplifier (Bose)																																																											
K	2007	Avalanche	Body	Assist Step Controller																																																											
K	2007	Avalanche	Body	Body Control Module																																																											
K	2007	Avalanche	Body	Body Control Module (aux.)																																																											
K	2007	Avalanche	Body	Digital Radio Receiver																																																											
K	2007	Avalanche	Body	Driver Door Switch																																																											
K	2007	Avalanche	Body	HVAC Control Module Auto																																																											
K	2007	Avalanche	Body	HVAC Control Module Manual																																																											
K	2007	Avalanche	Body	Instrument Panel Cluster																																																											
K	2007	Avalanche	Body	Memory Seat Module																																																											
K	2007	Avalanche	Body	Park Assist Module																																																											
K	2007	Avalanche	Body	Passenger Door Switch																																																											
K	2007	Avalanche	Body	Passenger Presence System																																																											
K	2007	Avalanche	Body	Radio																																																										
K	2007	Avalanche	Body	Rear Heated Seat Module																																																											
K	2007	Avalanche	Body	Rear HVAC/RSA																																																											
K	2007	Avalanche	Body	Rollover Sensor																																																											
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2007	Avalanche	Body	Theft Deterrent Module																																																											
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Suburban	Chassis	Electronic Suspension Control																																																												
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																												
K	2007	Suburban	Body	Amplifier (Bose)																																																												
K	2007	Suburban	Body	Assist Step Controller																																																												
K	2007	Suburban	Body	Body Control Module																																																												
K	2007	Suburban	Body	Body Control Module (aux.)																																																												
K	2007	Suburban	Body	Digital Radio Receiver																																																												
K	2007	Suburban	Body	Driver Door Switch																																																												
K	2007	Suburban	Body	HVAC Control Module Auto																																																												
K	2007	Suburban	Body	HVAC Control Module Manual																																																												
K	2007	Suburban	Body	Instrument Panel Cluster																																																												
K	2007	Suburban	Body	Lift Gate Module																																																												
K	2007	Suburban	Body	Memory Seat Module																																																												
K	2007	Suburban	Body	Park Assist Module																																																												
K	2007	Suburban	Body	Passenger Door Switch																																																												
K	2007	Suburban	Body	Passenger Presence System																																																												
K	2007	Suburban	Body	Radio																																																											
K	2007	Suburban	Body	Rear Heated Seat Module																																																												
K	2007	Suburban	Body	Rear HVAC/RSA																																																												
K	2007	Suburban	Body	Rollover Sensor																																																												
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2007	Suburban	Body	Theft Deterrent Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Silverado	Chassis	Electronic Suspension Control																																																										
K	2007	Silverado	Chassis	Trailer Brake Control Module																																																										
K	2007	Silverado	Body	Amplifier (Bose)																																																										
K	2007	Silverado	Body	Body Control Module																																																										
K	2007	Silverado	Body	Body Control Module (aux.)																																																										
K	2007	Silverado	Body	Digital Radio Receiver																																																										
K	2007	Silverado	Body	Driver Door Switch																																																										
K	2007	Silverado	Body	HVAC Control Module Auto																																																										
K	2007	Silverado	Body	HVAC Control Module Manual																																																										
K	2007	Silverado	Body	Instrument Panel Cluster																																																										
K	2007	Silverado	Body	Memory Seat Module																																																										
K	2007	Silverado	Body	Park Assist Module																																																										
K	2007	Silverado	Body	Passenger Door Switch																																																										
K	2007	Silverado	Body	Passenger Presence System																																																										
K	2007	Silverado	Body	Radio																																																										
K	2007	Silverado	Body	Rear Heated Seat Module																																																										
K	2007	Silverado	Body	Rear HVAC/RSA																																																										
K	2007	Silverado	Body	Rollover Sensor																																																										
K	2007	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2007	Silverado	Body	Theft Deterrent Module																																																										
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																											
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																											
K	2007	Tahoe	Body	Amplifier (Bose)																																																											
K	2007	Tahoe	Body	Assist Step Controller																																																											
K	2007	Tahoe	Body	Body Control Module																																																											
K	2007	Tahoe	Body	Body Control Module (aux.)																																																											
K	2007	Tahoe	Body	Digital Radio Receiver																																																											
K	2007	Tahoe	Body	Driver Door Switch																																																											
K	2007	Tahoe	Body	HVAC Control Module Auto																																																											
K	2007	Tahoe	Body	HVAC Control Module Manual																																																											
K	2007	Tahoe	Body	Instrument Panel Cluster																																																											
K	2007	Tahoe	Body	Lift Gate Module																																																											
K	2007	Tahoe	Body	Memory Seat Module																																																											
K	2007	Tahoe	Body	Park Assist Module																																																											
K	2007	Tahoe	Body	Passenger Door Switch																																																											
K	2007	Tahoe	Body	Passenger Presence System																																																											
K	2007	Tahoe	Body	Radio																																																											
K	2007	Tahoe	Body	Rear Heated Seat Module																																																											
K	2007	Tahoe	Body	Rear HVAC/RSA																																																											
K	2007	Tahoe	Body	Rollover Sensor																																																											
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																											
K	2007	Tahoe	Body	Theft Deterrent Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2008	Avalanche	Chassis	Electronic Brake Control Module																																																											
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																											
K	2008	Avalanche	Body	Amplifier (Bose)																																																											
K	2008	Avalanche	Body	Assist Step Controller																																																											
K	2008	Avalanche	Body	Body Control Module																																																											
K	2008	Avalanche	Body	Body Control Module (aux.)																																																											
K	2008	Avalanche	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2008	Avalanche	Body	Driver Door Switch																																																											
K	2008	Avalanche	Body	HVAC Control Module Auto																																																												
K	2008	Avalanche	Body	HVAC Control Module Manual																																																												
K	2008	Avalanche	Body	Instrument Panel Cluster																																																												
K	2008	Avalanche	Body	Memory Seat Module																																																												
K	2008	Avalanche	Body	Park Assist Module																																																												
K	2008	Avalanche	Body	Passenger Door Switch																																																												
K	2008	Avalanche	Body	Passenger Presence System																																																												
K	2008	Avalanche	Body	Radio																																																											
K	2008	Avalanche	Body	Rear Heated Seat Module																																																												
K	2008	Avalanche	Body	Rear HVAC/RSA																																																												
K	2008	Avalanche	Body	Rollover Sensor																																																												
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																												
K	2008	Avalanche	Body	Theft Deterrent Module																																																												
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2008	Suburban	Chassis	EBCM Under 8600 GVW																																																												
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2008	Suburban	Chassis	Electronic Suspension Control																																																												
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																												
K	2008	Suburban	Body	Amplifier (Bose)																																																												
K	2008	Suburban	Body	Assist Step Controller																																																												
K	2008	Suburban	Body	Body Control Module																																																												
K	2008	Suburban	Body	Body Control Module (aux.)																																																												
K	2008	Suburban	Body	Digital Radio Receiver																																																												
K	2008	Suburban	Body	Driver Door Switch																																																												
K	2008	Suburban	Body	HVAC Control Module Auto																																																												
K	2008	Suburban	Body	HVAC Control Module Manual																																																												
K	2008	Suburban	Body	Instrument Panel Cluster																																																												
K	2008	Suburban	Body	Lift Gate Module																																																												
K	2008	Suburban	Body	Memory Seat Module																																																												
K	2008	Suburban	Body	Park Assist Module																																																												
K	2008	Suburban	Body	Passenger Door Switch																																																												
K	2008	Suburban	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2008	Suburban	Body	Radio																																																											
K	2008	Suburban	Body	Rear Heated Seat Module																																																											
K	2008	Suburban	Body	Rear HVAC/RSA																																																											
K	2008	Suburban	Body	Rollover Sensor																																																											
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																																											
K	2008	Suburban	Body	Theft Deterrent Module																																																											
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																											
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2008	Silverado	Chassis	Electronic Suspension Control																																																											
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																											
K	2008	Silverado	Body	Amplifier (Bose)																																																											
K	2008	Silverado	Body	Body Control Module																																																											
K	2008	Silverado	Body	Body Control Module (aux.)																																																											
K	2008	Silverado	Body	Digital Radio Receiver																																																											
K	2008	Silverado	Body	Driver Door Switch																																																											
K	2008	Silverado	Body	HVAC Control Module Auto																																																											
K	2008	Silverado	Body	HVAC Control Module Manual																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2008	Silverado	Body	Instrument Panel Cluster																																																											
K	2008	Silverado	Body	Memory Seat Module																																																												
K	2008	Silverado	Body	Park Assist Module																																																												
K	2008	Silverado	Body	Passenger Door Switch																																																												
K	2008	Silverado	Body	Passenger Presence System																																																												
K	2008	Silverado	Body	Radio																																																												
K	2008	Silverado	Body	Rear Heated Seat Module																																																												
K	2008	Silverado	Body	Rear HVAC/RSA																																																												
K	2008	Silverado	Body	Rollover Sensor																																																												
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2008	Silverado	Body	Theft Deterrent Module																																																												
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2008	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																												
K	2008	Tahoe	Body	Amplifier (Bose)																																																												
K	2008	Tahoe	Body	Assist Step Controller																																																												
K	2008	Tahoe	Body	Body Control Module																																																												
K	2008	Tahoe	Body	Body Control Module (aux.)																																																												
K	2008	Tahoe	Body	Digital Radio Receiver																																																												
K	2008	Tahoe	Body	Driver Door Switch																																																												
K	2008	Tahoe	Body	HVAC Control Module Auto																																																												
K	2008	Tahoe	Body	HVAC Control Module Manual																																																												
K	2008	Tahoe	Body	Instrument Panel Cluster																																																												
K	2008	Tahoe	Body	Lift Gate Module																																																												
K	2008	Tahoe	Body	Memory Seat Module																																																												
K	2008	Tahoe	Body	Park Assist Module																																																												
K	2008	Tahoe	Body	Passenger Door Switch																																																												
K	2008	Tahoe	Body	Passenger Presence System																																																												
K	2008	Tahoe	Body	Radio																																																											
K	2008	Tahoe	Body	Rear Heated Seat Module																																																												
K	2008	Tahoe	Body	Rear HVAC/RSA																																																												
K	2008	Tahoe	Body	Rollover Sensor																																																												
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2008	Tahoe	Body	Theft Deterrent Module																																																												
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2008	Tahoe Hybrid	Body	Body Control Module																																																										
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2008	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2008	Tahoe Hybrid	Body	Memory Seat Module																																																										
K	2008	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2008	Tahoe Hybrid	Body	Radio																																																										
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																										
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																												
K	2009	Avalanche	Body	Amplifier (Bose)																																																													
K	2009	Avalanche	Body	Assist Step Controller																																																													
K	2009	Avalanche	Body	Body Control Module																																																													
K	2009	Avalanche	Body	Body Control Module (aux.)																																																													
K	2009	Avalanche	Body	Digital Radio Receiver																																																													
K	2009	Avalanche	Body	Driver Door Switch																																																													
K	2009	Avalanche	Body	HVAC Control Module Auto																																																													
K	2009	Avalanche	Body	HVAC Control Module Manual																																																													
K	2009	Avalanche	Body	Instrument Panel Cluster																																																													
K	2009	Avalanche	Body	Memory Seat Module																																																													
K	2009	Avalanche	Body	Park Assist Module																																																													
K	2009	Avalanche	Body	Passenger Door Switch																																																													
K	2009	Avalanche	Body	Passenger Presence System																																																													
K	2009	Avalanche	Body	Radio																																																													
K	2009	Avalanche	Body	Rear Heated Seat Module																																																													
K	2009	Avalanche	Body	Rear HVAC/RSA																																																													
K	2009	Avalanche	Body	Rollover Sensor																																																													
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																													
K	2009	Avalanche	Body	Theft Deterrent Module																																																													
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																													
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																													
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																													
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																													
K	2009	Cheyenne	Body	Amplifier (Bose)																																																													
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																													
K	2009	Cheyenne	Body	Digital Radio Receiver																																																													
K	2009	Cheyenne	Body	Driver Door Switch																																																													
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																													
K	2009	Cheyenne	Body	Park Assist Module																																																													
K	2009	Cheyenne	Body	Passenger Door Switch																																																													
K	2009	Cheyenne	Body	Passenger Presence System																																																													
K	2009	Cheyenne	Body	Rear Heated Seat Module																																																													
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																													
K	2009	Cheyenne	Body	Rollover Sensor																																																													
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																													
K	2009	Cheyenne	Body	Theft Deterrent Module																																																													
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																												
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2009	Suburban	Chassis	Electronic Suspension Control																																																												
K	2009	Suburban	Chassis	Trailer Brake Control Module																																																												
K	2009	Suburban	Body	Amplifier (Bose)																																																												
K	2009	Suburban	Body	Assist Step Controller																																																												
K	2009	Suburban	Body	Body Control Module																																																												
K	2009	Suburban	Body	Body Control Module (aux.)																																																												
K	2009	Suburban	Body	Digital Radio Receiver																																																												
K	2009	Suburban	Body	Driver Door Switch																																																												
K	2009	Suburban	Body	HVAC Control Module Auto																																																												
K	2009	Suburban	Body	HVAC Control Module Manual																																																												
K	2009	Suburban	Body	Instrument Panel Cluster																																																												
K	2009	Suburban	Body	Left Side Object Detection Module																																																												
K	2009	Suburban	Body	Lift Gate Module																																																												
K	2009	Suburban	Body	Memory Seat Module																																																												
K	2009	Suburban	Body	Park Assist Module																																																												
K	2009	Suburban	Body	Passenger Door Switch																																																												
K	2009	Suburban	Body	Passenger Presence System																																																												
K	2009	Suburban	Body	Radio																																																											
K	2009	Suburban	Body	Rear Heated Seat Module																																																												
K	2009	Suburban	Body	Rear HVAC/RSA																																																												
K	2009	Suburban	Body	Right Side Object Detection Module																																																												
K	2009	Suburban	Body	Rollover Sensor																																																												
K	2009	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2009	Suburban	Body	Theft Deterrent Module																																																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2009	Silverado	Chassis	Electronic Suspension Control																																																										
K	2009	Silverado	Chassis	Trailer Brake Control Module																																																										
K	2009	Silverado	Body	Amplifier (Bose)																																																										
K	2009	Silverado	Body	Body Control Module																																																										
K	2009	Silverado	Body	Body Control Module (aux.)																																																										
K	2009	Silverado	Body	Digital Radio Receiver																																																										
K	2009	Silverado	Body	Driver Door Switch																																																										
K	2009	Silverado	Body	HVAC Control Module Auto																																																										
K	2009	Silverado	Body	HVAC Control Module Manual																																																										
K	2009	Silverado	Body	Instrument Panel Cluster																																																										
K	2009	Silverado	Body	Memory Seat Module																																																										
K	2009	Silverado	Body	Park Assist Module																																																										
K	2009	Silverado	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2009	Silverado	Body	Passenger Presence System																																																										
K	2009	Silverado	Body	Radio																																																										
K	2009	Silverado	Body	Rear Heated Seat Module																																																										
K	2009	Silverado	Body	Rear HVAC/RSA																																																										
K	2009	Silverado	Body	Rollover Sensor																																																										
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2009	Silverado	Body	Theft Deterrent Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Silverado Hybrid	Body	Body Control Module																																																										
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2009	Silverado Hybrid	Body	HVAC Control Module																																																										
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Silverado Hybrid	Body	Memory Seat Module																																																										
K	2009	Silverado Hybrid	Body	Park Assist Module																																																										
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2009	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2009	Silverado Hybrid	Body	Radio																																																										
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																										
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2009	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																																												
K	2009	Tahoe	Body	Amplifier (Bose)																																																												
K	2009	Tahoe	Body	Assist Step Controller																																																												
K	2009	Tahoe	Body	Body Control Module																																																												
K	2009	Tahoe	Body	Body Control Module (aux.)																																																												
K	2009	Tahoe	Body	Digital Radio Receiver																																																												
K	2009	Tahoe	Body	Driver Door Switch																																																												
K	2009	Tahoe	Body	HVAC Control Module Auto																																																												
K	2009	Tahoe	Body	HVAC Control Module Manual																																																												
K	2009	Tahoe	Body	Instrument Panel Cluster																																																												
K	2009	Tahoe	Body	Left Side Object Detection Module																																																												
K	2009	Tahoe	Body	Lift Gate Module																																																												
K	2009	Tahoe	Body	Memory Seat Module																																																												
K	2009	Tahoe	Body	Park Assist Module																																																												
K	2009	Tahoe	Body	Passenger Door Switch																																																												
K	2009	Tahoe	Body	Passenger Presence System																																																												
K	2009	Tahoe	Body	Radio																																																											
K	2009	Tahoe	Body	Rear Heated Seat Module																																																												
K	2009	Tahoe	Body	Rear HVAC/RSA																																																												
K	2009	Tahoe	Body	Right Side Object Detection Module																																																												
K	2009	Tahoe	Body	Rollover Sensor																																																												
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2009	Tahoe	Body	Theft Deterrent Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																												
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
K	2009	Tahoe Hybrid	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2009	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2009	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2009	Tahoe Hybrid	Body	Radio																																																										
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																										
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Avalanche	Body	Amplifier (Bose)																																																										
K	2010	Avalanche	Body	Assist Step Controller																																																										
K	2010	Avalanche	Body	Body Control Module																																																										
K	2010	Avalanche	Body	Body Control Module (aux.)																																																										
K	2010	Avalanche	Body	Digital Radio Receiver																																																										
K	2010	Avalanche	Body	Driver Door Switch																																																										
K	2010	Avalanche	Body	HVAC Control Module Auto																																																										
K	2010	Avalanche	Body	HVAC Control Module Manual																																																										
K	2010	Avalanche	Body	Instrument Panel Cluster																																																										
K	2010	Avalanche	Body	Memory Seat Module																																																										
K	2010	Avalanche	Body	Park Assist Module																																																										
K	2010	Avalanche	Body	Passenger Door Switch																																																										
K	2010	Avalanche	Body	Passenger Presence System																																																										
K	2010	Avalanche	Body	Radio																																																										
K	2010	Avalanche	Body	Rear Heated Seat Module																																																										
K	2010	Avalanche	Body	Rear HVAC/RSA																																																										
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2010	Avalanche	Body	Theft Deterrent Module																																																										
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Cheyenne	Body	Amplifier (Bose)																																																										
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2010	Cheyenne	Body	Digital Radio Receiver																																																										
K	2010	Cheyenne	Body	Driver Door Switch																																																										
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2010	Cheyenne	Body	Park Assist Module																																																										
K	2010	Cheyenne	Body	Passenger Door Switch																																																										
K	2010	Cheyenne	Body	Passenger Presence System																																																										
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2010	Cheyenne	Body	Theft Deterrent Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2010	Suburban	Chassis	Electronic Suspension Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Body	Amplifier (Bose)																																																										
K	2010	Suburban	Body	Assist Step Controller																																																										
K	2010	Suburban	Body	Body Control Module																																																										
K	2010	Suburban	Body	Body Control Module (aux.)																																																										
K	2010	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2010	Suburban	Body	Driver Door Switch																																																											
K	2010	Suburban	Body	HVAC Control Module Auto																																																												
K	2010	Suburban	Body	HVAC Control Module Manual																																																												
K	2010	Suburban	Body	Instrument Panel Cluster																																																												
K	2010	Suburban	Body	Left Side Object Detection Module																																																												
K	2010	Suburban	Body	Lift Gate Module																																																												
K	2010	Suburban	Body	Memory Seat Module																																																												
K	2010	Suburban	Body	Park Assist Module																																																												
K	2010	Suburban	Body	Passenger Door Switch																																																												
K	2010	Suburban	Body	Passenger Presence System																																																												
K	2010	Suburban	Body	Radio																																																												
K	2010	Suburban	Body	Rear Heated Seat Module																																																												
K	2010	Suburban	Body	Rear HVAC/RSA																																																												
K	2010	Suburban	Body	Right Side Object Detection Module																																																												
K	2010	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2010	Suburban	Body	Theft Deterrent Module																																																												
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																												
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2010	Silverado	Chassis	Electronic Suspension Control																																																												
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2010	Silverado	Body	Amplifier (Bose)																																																												
K	2010	Silverado	Body	Body Control Module																																																												
K	2010	Silverado	Body	Body Control Module (aux.)																																																												
K	2010	Silverado	Body	Digital Radio Receiver																																																												
K	2010	Silverado	Body	Driver Door Switch																																																												
K	2010	Silverado	Body	HVAC Control Module Auto																																																												
K	2010	Silverado	Body	HVAC Control Module Manual																																																												
K	2010	Silverado	Body	Instrument Panel Cluster																																																												
K	2010	Silverado	Body	Memory Seat Module																																																												
K	2010	Silverado	Body	Park Assist Module																																																												
K	2010	Silverado	Body	Passenger Door Switch																																																												
K	2010	Silverado	Body	Passenger Presence System																																																												
K	2010	Silverado	Body	Radio																																																												
K	2010	Silverado	Body	Rear Heated Seat Module																																																												
K	2010	Silverado	Body	Rear HVAC/RSA																																																												
K	2010	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2010	Silverado	Body	Theft Deterrent Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Silverado Hybrid	Body	Body Control Module																																																												
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2010	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2010	Silverado Hybrid	Body	Heated Seat Module																																																												
K	2010	Silverado Hybrid	Body	HVAC Control Module																																																												
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2010	Silverado Hybrid	Body	Park Assist Module																																																												
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2010	Silverado Hybrid	Body	Passenger Presence System																																																												
K	2010	Silverado Hybrid	Body	Radio																																																												
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Tahoe	Body	Amplifier (Bose)																																																										
K	2010	Tahoe	Body	Assist Step Controller																																																										
K	2010	Tahoe	Body	Body Control Module																																																										
K	2010	Tahoe	Body	Body Control Module (aux.)																																																										
K	2010	Tahoe	Body	Digital Radio Receiver																																																										
K	2010	Tahoe	Body	Driver Door Switch																																																										
K	2010	Tahoe	Body	HVAC Control Module Auto																																																										
K	2010	Tahoe	Body	HVAC Control Module Manual																																																										
K	2010	Tahoe	Body	Instrument Panel Cluster																																																										
K	2010	Tahoe	Body	Left Side Object Detection Module																																																										
K	2010	Tahoe	Body	Lift Gate Module																																																										
K	2010	Tahoe	Body	Memory Seat Module																																																										
K	2010	Tahoe	Body	Park Assist Module																																																										
K	2010	Tahoe	Body	Passenger Door Switch																																																										
K	2010	Tahoe	Body	Passenger Presence System																																																										
K	2010	Tahoe	Body	Radio																																																										
K	2010	Tahoe	Body	Rear Heated Seat Module																																																										
K	2010	Tahoe	Body	Rear HVAC/RSA																																																										
K	2010	Tahoe	Body	Right Side Object Detection Module																																																										
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2010	Tahoe	Body	Theft Deterrent Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Tahoe Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2010	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2010	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2010	Tahoe Hybrid	Body	Radio																																																										
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2011	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Avalanche	Body	Amplifier (Bose)																																																										
K	2011	Avalanche	Body	Assist Step Controller																																																										
K	2011	Avalanche	Body	Body Control Module																																																										
K	2011	Avalanche	Body	Body Control Module (aux.)																																																										
K	2011	Avalanche	Body	Digital Radio Receiver																																																										
K	2011	Avalanche	Body	Driver Door Switch																																																										
K	2011	Avalanche	Body	HVAC Control Module Auto																																																										
K	2011	Avalanche	Body	HVAC Control Module Manual																																																										
K	2011	Avalanche	Body	Instrument Panel Cluster																																																										
K	2011	Avalanche	Body	Memory Seat Module																																																										
K	2011	Avalanche	Body	Park Assist Module																																																										
K	2011	Avalanche	Body	Passenger Door Switch																																																										
K	2011	Avalanche	Body	Passenger Presence System																																																										
K	2011	Avalanche	Body	Radio																																																										
K	2011	Avalanche	Body	Rear Heated Seat Module																																																										
K	2011	Avalanche	Body	Rear HVAC/RSA																																																										
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2011	Avalanche	Body	Theft Deterrent Module																																																										
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																											
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																											
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Cheyenne	Body	Amplifier (Bose)																																																											
K	2011	Cheyenne	Body	Body Control Module																																																											
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2011	Cheyenne	Body	Digital Radio Receiver																																																											
K	2011	Cheyenne	Body	Driver Door Switch																																																											
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2011	Cheyenne	Body	Park Assist Module																																																											
K	2011	Cheyenne	Body	Passenger Door Switch																																																											
K	2011	Cheyenne	Body	Passenger Presence System																																																											
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																											
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
K	2011	Cheyenne	Body	Theft Deterrent Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																											
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2011	Suburban	Chassis	Electronic Suspension Control																																																											
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Suburban	Body	Amplifier (Bose)																																																											
K	2011	Suburban	Body	Assist Step Controller																																																											
K	2011	Suburban	Body	Body Control Module																																																											
K	2011	Suburban	Body	Body Control Module (aux.)																																																											
K	2011	Suburban	Body	Digital Radio Receiver																																																											
K	2011	Suburban	Body	Driver Door Switch																																																											
K	2011	Suburban	Body	HVAC Control Module Auto																																																											
K	2011	Suburban	Body	HVAC Control Module Manual																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2011	Suburban	Body	Instrument Panel Cluster																																																											
K	2011	Suburban	Body	Left Side Object Detection Module																																																												
K	2011	Suburban	Body	Lift Gate Module																																																												
K	2011	Suburban	Body	Memory Seat Module																																																												
K	2011	Suburban	Body	Park Assist Module																																																												
K	2011	Suburban	Body	Passenger Door Switch																																																												
K	2011	Suburban	Body	Passenger Presence System																																																												
K	2011	Suburban	Body	Radio																																																												
K	2011	Suburban	Body	Rear Heated Seat Module																																																												
K	2011	Suburban	Body	Rear HVAC/RSA																																																												
K	2011	Suburban	Body	Right Side Object Detection Module																																																												
K	2011	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2011	Suburban	Body	Theft Deterrent Module																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2011	Silverado	Chassis	Electronic Suspension Control																																																												
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2011	Silverado	Body	Amplifier (Bose)																																																												
K	2011	Silverado	Body	Body Control Module																																																												
K	2011	Silverado	Body	Body Control Module (aux.)																																																												
K	2011	Silverado	Body	Digital Radio Receiver																																																												
K	2011	Silverado	Body	Driver Door Switch																																																												
K	2011	Silverado	Body	HVAC Control Module Auto																																																												
K	2011	Silverado	Body	HVAC Control Module Manual																																																												
K	2011	Silverado	Body	Instrument Panel Cluster																																																												
K	2011	Silverado	Body	Memory Seat Module																																																												
K	2011	Silverado	Body	Park Assist Module																																																												
K	2011	Silverado	Body	Passenger Door Switch																																																												
K	2011	Silverado	Body	Passenger Presence System																																																												
K	2011	Silverado	Body	Radio																																																												
K	2011	Silverado	Body	Rear Heated Seat Module																																																												
K	2011	Silverado	Body	Rear HVAC/RSA																																																												
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2011	Silverado	Body	Theft Deterrent Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2011	Silverado Hybrid	Body	Body Control Module																																																												
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																												
K	2011	Silverado Hybrid	Body	HVAC Control Module																																																												
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2011	Silverado Hybrid	Body	Park Assist Module																																																												
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2011	Silverado Hybrid	Body	Passenger Presence System																																																												
K	2011	Silverado Hybrid	Body	Radio																																																												
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2011	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Tahoe	Body	Amplifier (Bose)																																																										
K	2011	Tahoe	Body	Assist Step Controller																																																										
K	2011	Tahoe	Body	Body Control Module																																																										
K	2011	Tahoe	Body	Body Control Module (aux.)																																																										
K	2011	Tahoe	Body	Digital Radio Receiver																																																										
K	2011	Tahoe	Body	Driver Door Switch																																																										
K	2011	Tahoe	Body	HVAC Control Module Auto																																																										
K	2011	Tahoe	Body	HVAC Control Module Manual																																																										
K	2011	Tahoe	Body	Instrument Panel Cluster																																																										
K	2011	Tahoe	Body	Left Side Object Detection Module																																																										
K	2011	Tahoe	Body	Lift Gate Module																																																										
K	2011	Tahoe	Body	Memory Seat Module																																																										
K	2011	Tahoe	Body	Park Assist Module																																																										
K	2011	Tahoe	Body	Passenger Door Switch																																																										
K	2011	Tahoe	Body	Passenger Presence System																																																										
K	2011	Tahoe	Body	Radio																																																										
K	2011	Tahoe	Body	Rear Heated Seat Module																																																										
K	2011	Tahoe	Body	Rear HVAC/RSA																																																										
K	2011	Tahoe	Body	Right Side Object Detection Module																																																										
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2011	Tahoe	Body	Theft Deterrent Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2011	Tahoe Hybrid	Body	Body Control Module																																																										
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2011	Tahoe Hybrid	Body	HVAC Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																																											
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																											
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																																											
K	2011	Tahoe Hybrid	Body	Radio																																																											
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2012	Avalanche	Chassis	Electronic Brake Control Module																																																											
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Avalanche	Body	Amplifier (Bose)																																																											
K	2012	Avalanche	Body	Assist Step Controller																																																											
K	2012	Avalanche	Body	Body Control Module																																																											
K	2012	Avalanche	Body	Body Control Module (aux.)																																																											
K	2012	Avalanche	Body	Digital Radio Receiver																																																											
K	2012	Avalanche	Body	Driver Door Switch																																																											
K	2012	Avalanche	Body	HVAC Control Module Auto																																																											
K	2012	Avalanche	Body	HVAC Control Module Manual																																																											
K	2012	Avalanche	Body	Instrument Panel Cluster																																																											
K	2012	Avalanche	Body	Memory Seat Module																																																											
K	2012	Avalanche	Body	Navigation Radio																																																											
K	2012	Avalanche	Body	Park Assist Module																																																											
K	2012	Avalanche	Body	Passenger Door Switch																																																											
K	2012	Avalanche	Body	Passenger Presence System																																																											
K	2012	Avalanche	Body	Radio																																																											
K	2012	Avalanche	Body	Rear Heated Seat Module																																																											
K	2012	Avalanche	Body	Rear HVAC/RSA																																																											
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2012	Avalanche	Body	Theft Deterrent Module																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Cheyenne	Body	Amplifier (Bose)																																																										
K	2012	Cheyenne	Body	Body Control Module																																																										
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2012	Cheyenne	Body	Digital Radio Receiver																																																										
K	2012	Cheyenne	Body	Driver Door Switch																																																										
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2012	Cheyenne	Body	Park Assist Module																																																										
K	2012	Cheyenne	Body	Passenger Door Switch																																																										
K	2012	Cheyenne	Body	Passenger Presence System																																																										
K	2012	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2012	Cheyenne	Body	Theft Deterrent Module																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									V	
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2012	Suburban	Chassis	Electronic Suspension Control																																																										
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Suburban	Body	Amplifier (Bose)																																																										
K	2012	Suburban	Body	Assist Step Controller																																																										
K	2012	Suburban	Body	Body Control Module																																																										
K	2012	Suburban	Body	Body Control Module (aux.)																																																										
K	2012	Suburban	Body	Digital Radio Receiver																																																										
K	2012	Suburban	Body	Driver Door Switch																																																										
K	2012	Suburban	Body	HVAC Control Module Auto																																																										
K	2012	Suburban	Body	HVAC Control Module Manual																																																										
K	2012	Suburban	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2012	Suburban	Body	Left Side Object Detection Module																																																											
K	2012	Suburban	Body	Lift Gate Module																																																												
K	2012	Suburban	Body	Memory Seat Module																																																												
K	2012	Suburban	Body	Navigation Radio																																																												
K	2012	Suburban	Body	Park Assist Module																																																												
K	2012	Suburban	Body	Passenger Door Switch																																																												
K	2012	Suburban	Body	Passenger Presence System																																																												
K	2012	Suburban	Body	Radio																																																												
K	2012	Suburban	Body	Rear Heated Seat Module																																																												
K	2012	Suburban	Body	Rear HVAC/RSA																																																												
K	2012	Suburban	Body	Right Side Object Detection Module																																																												
K	2012	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2012	Suburban	Body	Theft Deterrent Module																																																												
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																												
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2012	Silverado	Chassis	Electronic Suspension Control																																																											
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2012	Silverado	Body	Amplifier (Bose)																																																												
K	2012	Silverado	Body	Body Control Module																																																												
K	2012	Silverado	Body	Body Control Module (aux.)																																																												
K	2012	Silverado	Body	Digital Radio Receiver																																																												
K	2012	Silverado	Body	Driver Door Switch																																																												
K	2012	Silverado	Body	HVAC Control Module Auto																																																												
K	2012	Silverado	Body	HVAC Control Module Manual																																																												
K	2012	Silverado	Body	Instrument Panel Cluster																																																												
K	2012	Silverado	Body	Memory Seat Module																																																												
K	2012	Silverado	Body	Navigation Radio																																																												
K	2012	Silverado	Body	Park Assist Module																																																												
K	2012	Silverado	Body	Passenger Door Switch																																																												
K	2012	Silverado	Body	Passenger Presence System																																																												
K	2012	Silverado	Body	Radio																																																												
K	2012	Silverado	Body	Rear Heated Seat Module																																																												
K	2012	Silverado	Body	Rear HVAC/RSA																																																												
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2012	Silverado	Body	Theft Deterrent Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2012	Silverado Hybrid	Body	Body Control Module																																																												
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2012	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2012	Silverado Hybrid	Body	Heated Seat Module																																																												
K	2012	Silverado Hybrid	Body	HVAC Control Module																																																												
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2012	Silverado Hybrid	Body	Navigation Radio																																																												
K	2012	Silverado Hybrid	Body	Park Assist Module																																																												
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2012	Silverado Hybrid	Body	Passenger Presence System																																																												
K	2012	Silverado Hybrid	Body	Radio																																																												
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2012	Tahoe	Chassis	EBCM with Trailer Brake																																																										
K	2012	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Tahoe	Body	Amplifier (Bose)																																																										
K	2012	Tahoe	Body	Assist Step Controller																																																										
K	2012	Tahoe	Body	Body Control Module																																																										
K	2012	Tahoe	Body	Body Control Module (aux.)																																																										
K	2012	Tahoe	Body	Digital Radio Receiver																																																										
K	2012	Tahoe	Body	Driver Door Switch																																																										
K	2012	Tahoe	Body	HVAC Control Module Auto																																																										
K	2012	Tahoe	Body	HVAC Control Module Manual																																																										
K	2012	Tahoe	Body	Instrument Panel Cluster																																																										
K	2012	Tahoe	Body	Left Side Object Detection Module																																																										
K	2012	Tahoe	Body	Lift Gate Module																																																										
K	2012	Tahoe	Body	Memory Seat Module																																																										
K	2012	Tahoe	Body	Navigation Radio																																																										
K	2012	Tahoe	Body	Park Assist Module																																																										
K	2012	Tahoe	Body	Passenger Door Switch																																																										
K	2012	Tahoe	Body	Passenger Presence System																																																										
K	2012	Tahoe	Body	Radio																																																										
K	2012	Tahoe	Body	Rear Heated Seat Module																																																										
K	2012	Tahoe	Body	Rear HVAC/RSA																																																										
K	2012	Tahoe	Body	Right Side Object Detection Module																																																										
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2012	Tahoe	Body	Theft Deterrent Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2012	Tahoe Hybrid	Body	Body Control Module																																																										
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2012	Tahoe Hybrid	Body	HVAC Control Module																																																												
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																																												
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																												
K	2012	Tahoe Hybrid	Body	Park Assist Module																																																												
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																												
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																																												
K	2012	Tahoe Hybrid	Body	Radio																																																												
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2013	Avalanche	Chassis	Electronic Brake Control Module																																																												
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																												
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Avalanche	Body	Amplifier (Bose)																																																												
K	2013	Avalanche	Body	Assist Step Controller																																																												
K	2013	Avalanche	Body	Body Control Module																																																												
K	2013	Avalanche	Body	Body Control Module (aux.)																																																												
K	2013	Avalanche	Body	Digital Radio Receiver																																																												
K	2013	Avalanche	Body	Driver Door Switch																																																												
K	2013	Avalanche	Body	HVAC Control Module Auto																																																												
K	2013	Avalanche	Body	HVAC Control Module Manual																																																												
K	2013	Avalanche	Body	Instrument Panel Cluster																																																												
K	2013	Avalanche	Body	Memory Seat Module																																																												
K	2013	Avalanche	Body	Navigation Radio																																																												
K	2013	Avalanche	Body	Park Assist Module																																																												
K	2013	Avalanche	Body	Passenger Door Switch																																																												
K	2013	Avalanche	Body	Passenger Presence System																																																												
K	2013	Avalanche	Body	Radio																																																												
K	2013	Avalanche	Body	Rear Heated Seat Module																																																												
K	2013	Avalanche	Body	Rear HVAC/RSA																																																												
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																												
K	2013	Avalanche	Body	Theft Deterrent Module																																																												
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Cheyenne	Body	Amplifier (Bose)																																																										
K	2013	Cheyenne	Body	Body Control Module																																																										
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2013	Cheyenne	Body	Digital Radio Receiver																																																										
K	2013	Cheyenne	Body	Driver Door Switch																																																										
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2013	Cheyenne	Body	Park Assist Module																																																										
K	2013	Cheyenne	Body	Passenger Door Switch																																																										
K	2013	Cheyenne	Body	Passenger Presence System																																																										
K	2013	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2013	Cheyenne	Body	Theft Deterrent Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2013	Suburban	Chassis	Electronic Suspension Control																																																										
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Suburban	Body	Amplifier (Bose)																																																										
K	2013	Suburban	Body	Assist Step Controller																																																										
K	2013	Suburban	Body	Body Control Module																																																										
K	2013	Suburban	Body	Body Control Module (aux.)																																																										
K	2013	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2013	Suburban	Body	Driver Door Switch																																																											
K	2013	Suburban	Body	HVAC Control Module Auto																																																												
K	2013	Suburban	Body	HVAC Control Module Manual																																																												
K	2013	Suburban	Body	Instrument Panel Cluster																																																												
K	2013	Suburban	Body	Left Side Object Detection Module																																																												
K	2013	Suburban	Body	Lift Gate Module																																																												
K	2013	Suburban	Body	Memory Seat Module																																																												
K	2013	Suburban	Body	Navigation Radio																																																												
K	2013	Suburban	Body	Park Assist Module																																																												
K	2013	Suburban	Body	Passenger Door Switch																																																												
K	2013	Suburban	Body	Passenger Presence System																																																												
K	2013	Suburban	Body	Radio																																																												
K	2013	Suburban	Body	Rear Heated Seat Module																																																												
K	2013	Suburban	Body	Rear HVAC/RSA																																																												
K	2013	Suburban	Body	Right Side Object Detection Module																																																												
K	2013	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2013	Suburban	Body	Theft Deterrent Module																																																												
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																												
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																												
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2013	Silverado	Chassis	Electronic Suspension Control																																																												
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2013	Silverado	Body	Amplifier (Bose)																																																												
K	2013	Silverado	Body	Body Control Module																																																												
K	2013	Silverado	Body	Body Control Module (aux.)																																																												
K	2013	Silverado	Body	Digital Radio Receiver																																																												
K	2013	Silverado	Body	Driver Door Switch																																																												
K	2013	Silverado	Body	HVAC Control Module Auto																																																												
K	2013	Silverado	Body	HVAC Control Module Manual																																																												
K	2013	Silverado	Body	Instrument Panel Cluster																																																												
K	2013	Silverado	Body	Memory Seat Module																																																												
K	2013	Silverado	Body	Navigation Radio																																																												
K	2013	Silverado	Body	Park Assist Module																																																												
K	2013	Silverado	Body	Passenger Door Switch																																																												
K	2013	Silverado	Body	Passenger Presence System																																																												
K	2013	Silverado	Body	Radio																																																												
K	2013	Silverado	Body	Rear Heated Seat Module																																																												
K	2013	Silverado	Body	Rear HVAC/RSA																																																												
K	2013	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2013	Silverado	Body	Theft Deterrent Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2013	Silverado Hybrid	Body	Body Control Module																																																												
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2013	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2013	Silverado Hybrid	Body	Heated Seat Module																																																												
K	2013	Silverado Hybrid	Body	HVAC Control Module																																																												
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2013	Silverado Hybrid	Body	Navigation Radio																																																												
K	2013	Silverado Hybrid	Body	Park Assist Module																																																												
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2013	Silverado Hybrid	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2013	Silverado Hybrid	Body	Radio																																																										
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									V	
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe	Body	Amplifier (Bose)																																																										
K	2013	Tahoe	Body	Assist Step Controller																																																										
K	2013	Tahoe	Body	Body Control Module																																																										
K	2013	Tahoe	Body	Body Control Module (aux.)																																																										
K	2013	Tahoe	Body	Digital Radio Receiver																																																										
K	2013	Tahoe	Body	Driver Door Switch																																																										
K	2013	Tahoe	Body	HVAC Control Module Auto																																																										
K	2013	Tahoe	Body	HVAC Control Module Manual																																																										
K	2013	Tahoe	Body	Instrument Panel Cluster																																																										
K	2013	Tahoe	Body	Left Side Object Detection Module																																																										
K	2013	Tahoe	Body	Lift Gate Module																																																										
K	2013	Tahoe	Body	Memory Seat Module																																																										
K	2013	Tahoe	Body	Navigation Radio																																																										
K	2013	Tahoe	Body	Park Assist Module																																																										
K	2013	Tahoe	Body	Passenger Door Switch																																																										
K	2013	Tahoe	Body	Passenger Presence System																																																										
K	2013	Tahoe	Body	Radio																																																										
K	2013	Tahoe	Body	Rear Heated Seat Module																																																										
K	2013	Tahoe	Body	Rear HVAC/RSA																																																										
K	2013	Tahoe	Body	Right Side Object Detection Module																																																										
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2013	Tahoe	Body	Theft Deterrent Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																													
K	2013	Tahoe Hybrid	Body	Body Control Module																																																													
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																													
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																													
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																													
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																													
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																																													
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																													
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																													
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																																													
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																													
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																													
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																													
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																																													
K	2013	Tahoe Hybrid	Body	Radio																																																													
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																													
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																													
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																													
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																													
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																													
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																													
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																													
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																													
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																													
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																													
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																													
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																													
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																													
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																													
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																													
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																													
K	2014	Cheyenne	Chassis	Power Steering Control Module																																																													
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																													
K	2014	Cheyenne	Body	Body Control Module																																																													
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
K	2014	Cheyenne	Body	Passenger Presence Module																																																													
K	2014	Cheyenne	Body	Instrument Cluster																																																													
K	2014	Cheyenne	Body	Radio Control																																																													
K	2014	Cheyenne	Body	HVAC Control																																																													
K	2014	Cheyenne	Body	Radio																																																													
K	2014	Cheyenne	Body	Amplifier																																																													
K	2014	Cheyenne	Body	Media Disc Player																																																													
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																													
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2014	Cheyenne	Body	HVAC Control Module																																																											
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																												
K	2014	Cheyenne	Body	Parking Assist Control Module																																																												
K	2014	Cheyenne	Body	Frontview Camera Module																																																												
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2014	Silverado	Chassis	Electronic Brake Control Module																																																												
K	2014	Silverado	Chassis	Parking Brake Control Module																																																												
K	2014	Silverado	Chassis	Power Steering Control Module																																																												
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2014	Silverado	Body	Body Control Module																																																												
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Silverado	Body	Passenger Presence Module																																																												
K	2014	Silverado	Body	Instrument Cluster																																																												
K	2014	Silverado	Body	Radio Control																																																												
K	2014	Silverado	Body	HVAC Control																																																												
K	2014	Silverado	Body	Radio																																																												
K	2014	Silverado	Body	Amplifier																																																												
K	2014	Silverado	Body	Media Disc Player																																																												
K	2014	Silverado	Body	Human Machine Interface Control Module																																																												
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																												
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																												
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																												
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																												
K	2014	Silverado	Body	Parking Assist Control Module																																																												
K	2014	Silverado	Body	Frontview Camera Module																																																												
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																												
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																												
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																												
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																												
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2014	Silverado HD	Chassis	Suspension Control Module																																																										
K	2014	Silverado HD	Body	Body Control Module																																																										
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Silverado HD	Body	Passenger Presence Module																																																										
K	2014	Silverado HD	Body	Instrument Cluster																																																										
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
K	2014	Silverado HD	Body	Base Radio																																																										
K	2014	Silverado HD	Body	Navigation Radio																																																										
K	2014	Silverado HD	Body	Uplevel Radio																																																										
K	2014	Silverado HD	Body	Amplifier																																																										
K	2014	Silverado HD	Body	Rear Audio Control Module																																																										
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																										
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																										
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																											V																															
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																											V																															
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																											V																															
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Silverado HD	Body	Seat Memory Control Module																																																										
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																										
K	2014	Silverado HD	Body	Parking Assist Control Module																				V																																						
K	2014	Silverado HD	Body	Theft Deterrent Module																																																										
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																										
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2014	Suburban	Chassis	Parking Brake Control Module																																																										
K	2014	Suburban	Chassis	Suspension Control Module																																																										
K	2014	Suburban	Body	Body Control Module																																																										
K	2014	Suburban	Body	Auxiliary Body Control Module																																																										
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Suburban	Body	Passenger Presence Module																																																										
K	2014	Suburban	Body	Instrument Cluster																																																										
K	2014	Suburban	Body	Base Radio																																																										
K	2014	Suburban	Body	Navigation Radio																																																										
K	2014	Suburban	Body	Uplevel Radio																																																										
K	2014	Suburban	Body	Amplifier																																																										
K	2014	Suburban	Body	Rear Audio Control Module																																																										
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																										
K	2014	Suburban	Body	Personal Audio Link Control Module																																																										
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																											V																																
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																											V																																
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																											
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																											
K	2014	Suburban	Body	Liftgate Control Module																																																											
K	2014	Suburban	Body	Seat Memory Control Module																																																											
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																											
K	2014	Suburban	Body	Assist Step Control Module																																																											
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																											
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																											
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																											
K	2014	Suburban	Body	Parking Assist Control Module																				V																																							
K	2014	Suburban	Body	Theft Deterrent Module																																																											
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																											
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																											
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																											
K	2014	Tahoe	Chassis	Suspension Control Module																																																											
K	2014	Tahoe	Body	Body Control Module																																																											
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																											
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2014	Tahoe	Body	Passenger Presence Module																																																											
K	2014	Tahoe	Body	Instrument Cluster																																																											
K	2014	Tahoe	Body	Base Radio																																																											
K	2014	Tahoe	Body	Navigation Radio																																																											
K	2014	Tahoe	Body	Uplevel Radio																																																											
K	2014	Tahoe	Body	Amplifier																																																											
K	2014	Tahoe	Body	Rear Audio Control Module																																																											
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																											
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																											
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																											
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																											V																																
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																											V																																
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																											
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																											
K	2014	Tahoe	Body	Liftgate Control Module																																																											
K	2014	Tahoe	Body	Seat Memory Control Module																																																											
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																											
K	2014	Tahoe	Body	Assist Step Control Module																																																											
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																											
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																											
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																											
K	2014	Tahoe	Body	Parking Assist Control Module																				V																																							
K	2014	Tahoe	Body	Theft Deterrent Module																																																											
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																												
K	2015	Cheyenne	Chassis	Power Steering Control Module																																																												
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Cheyenne	Chassis	Suspension Control Module																																																												
K	2015	Cheyenne	Body	Body Control Module																																																												
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Cheyenne	Body	Passenger Presence Module																																																												
K	2015	Cheyenne	Body	Instrument Cluster																																																												
K	2015	Cheyenne	Body	Radio Controls																																																												
K	2015	Cheyenne	Body	HVAC Controls																																																												
K	2015	Cheyenne	Body	Radio																																																												
K	2015	Cheyenne	Body	Amplifier																																																												
K	2015	Cheyenne	Body	Media Disc Player																																																												
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																												
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																												
K	2015	Cheyenne	Body	HVAC Control Module																																																												
K	2015	Cheyenne	Body	Parking Assist Control Module																																																												
K	2015	Cheyenne	Body	Frontview Camera Module																																																												
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																												
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2015	Silverado	Chassis	Electronic Brake Control Module																																																												
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																												
K	2015	Silverado	Chassis	Power Steering Control Module																																																												
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Silverado	Chassis	Suspension Control Module																																																												
K	2015	Silverado	Body	Body Control Module																																																												
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Silverado	Body	Passenger Presence Module																																																												
K	2015	Silverado	Body	Instrument Cluster																																																												
K	2015	Silverado	Body	Radio Controls																																																												
K	2015	Silverado	Body	HVAC Controls																																																												
K	2015	Silverado	Body	Radio																																																												
K	2015	Silverado	Body	Amplifier																																																												
K	2015	Silverado	Body	Media Disc Player																																																												
K	2015	Silverado	Body	Human Machine Interface Control Module																																																												
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																																												
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																												
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																												
K	2015	Silverado	Body	Parking Assist Control Module																																																												
K	2015	Silverado	Body	Frontview Camera Module																																																												
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																												
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2015	Suburban	Chassis	Electronic Brake Control Module																																																												
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																												
K	2015	Suburban	Chassis	Parking Brake Control Module																																																												
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2015	Suburban	Chassis	Power Steering Control Module																																																												
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Suburban	Chassis	Suspension Control Module																																																												
K	2015	Suburban	Body	Body Control Module																																																												
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Suburban	Body	Passenger Presence Module																																																												
K	2015	Suburban	Body	Instrument Cluster																																																												
K	2015	Suburban	Body	Radio Controls																																																												
K	2015	Suburban	Body	HVAC Controls																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2015	Suburban	Body	Radio																																																											
K	2015	Suburban	Body	Amplifier																																																											
K	2015	Suburban	Body	Media Disc Player																																																											
K	2015	Suburban	Body	Human Machine Interface Control Module																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2015	Suburban	Body	HVAC Control Module																																																											
K	2015	Suburban	Body	Liftgate Control Module																																																											
K	2015	Suburban	Body	Keyless Entry Control Module																																																											
K	2015	Suburban	Body	Assist Step Control Module																																																											
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																											
K	2015	Suburban	Body	Parking Assist Control Module																																																											
K	2015	Suburban	Body	Frontview Camera Module																																																											
K	2015	Suburban	Body	Steering Column Lock Control Module																																																											
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																											
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																											
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																											
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																											
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																											
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																											
K	2015	Tahoe	Chassis	Power Steering Control Module																																																											
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Tahoe	Chassis	Suspension Control Module																																																											
K	2015	Tahoe	Body	Body Control Module																																																											
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Tahoe	Body	Passenger Presence Module																																																											
K	2015	Tahoe	Body	Instrument Cluster																																																											
K	2015	Tahoe	Body	Radio Controls																																																											
K	2015	Tahoe	Body	HVAC Controls																																																											
K	2015	Tahoe	Body	Radio																																																											
K	2015	Tahoe	Body	Amplifier																																																											
K	2015	Tahoe	Body	Media Disc Player																																																											
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2015	Tahoe	Body	HVAC Control Module																																																											
K	2015	Tahoe	Body	Liftgate Control Module																																																											
K	2015	Tahoe	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2015	Tahoe	Body	Assist Step Control Module																																																										
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2015	Tahoe	Body	Parking Assist Control Module																																																										
K	2015	Tahoe	Body	Frontview Camera Module																																																										
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																										
K	2015	Tahoe	Body	Battery Energy Control Module																																																										
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																										
K	2016	Cheyenne	Chassis	Power Steering Control Module																																																										
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Cheyenne	Chassis	Suspension Control Module																																																										
K	2016	Cheyenne	Body	Body Control Module																																																										
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Cheyenne	Body	Passenger Presence Module																																																										
K	2016	Cheyenne	Body	Instrument Cluster																																																										
K	2016	Cheyenne	Body	Radio Controls																																																										
K	2016	Cheyenne	Body	HVAC Controls																																																										
K	2016	Cheyenne	Body	Radio																																																										
K	2016	Cheyenne	Body	Amplifier																																																										
K	2016	Cheyenne	Body	Media Disc Player																																																										
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																										
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
K	2016	Cheyenne	Body	HVAC Control Module																																																										
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																										
K	2016	Cheyenne	Body	Parking Assist Control Module																																																										
K	2016	Cheyenne	Body	Frontview Camera Module																																																										
K	2016	Cheyenne	Body	Frontview Camera Module																																																										
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																												
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2016	Silverado	Chassis	Electronic Brake Control Module																																																												
K	2016	Silverado	Chassis	Power Steering Control Module																																																												
K	2016	Silverado	Chassis	Power Steering Control Module																																																												
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2016	Silverado	Chassis	Suspension Control Module																																																												
K	2016	Silverado	Body	Body Control Module																																																												
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2016	Silverado	Body	Passenger Presence Module																																																												
K	2016	Silverado	Body	Instrument Cluster																																																												
K	2016	Silverado	Body	Radio Controls																																																												
K	2016	Silverado	Body	HVAC Controls																																																												
K	2016	Silverado	Body	Radio (IO3)																																																												
K	2016	Silverado	Body	Radio (IOB)																																																												
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																												
K	2016	Silverado	Body	Amplifier																																																												
K	2016	Silverado	Body	Media Disc Player																																																												
K	2016	Silverado	Body	Human Machine Interface Control Module																																																												
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																												
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																												
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																												
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																												
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																												
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																												
K	2016	Silverado	Body	Parking Assist Control Module																																																												
K	2016	Silverado	Body	Frontview Camera Module																																																												
K	2016	Silverado	Body	Frontview Camera Module																																																												
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2016	Suburban	Chassis	Electronic Brake Control Module																																																												
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																												
K	2016	Suburban	Chassis	Parking Brake Control Module																																																												
K	2016	Suburban	Chassis	Power Steering Control Module																																																												
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2016	Suburban	Chassis	Suspension Control Module																																																												
K	2016	Suburban	Body	Body Control Module																																																												
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2016	Suburban	Body	Passenger Presence Module																																																											
K	2016	Suburban	Body	Instrument Cluster																																																												
K	2016	Suburban	Body	Radio Controls																																																												
K	2016	Suburban	Body	HVAC Controls																																																												
K	2016	Suburban	Body	Radio																																																												
K	2016	Suburban	Body	Amplifier																																																												
K	2016	Suburban	Body	Media Disc Player																																																												
K	2016	Suburban	Body	Human Machine Interface Control Module																																																												
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																																												
K	2016	Suburban	Body	HVAC Control Module																																																												
K	2016	Suburban	Body	Liftgate Control Module																																																												
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																												
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																												
K	2016	Suburban	Body	Keyless Entry Control Module																																																												
K	2016	Suburban	Body	Assist Step Control Module																																																												
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																												
K	2016	Suburban	Body	Parking Assist Control Module																																																												
K	2016	Suburban	Body	Frontview Camera Module																																																												
K	2016	Suburban	Body	Steering Column Lock Control Module																																																												
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																												
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																												
K	2016	Tahoe	Chassis	Power Steering Control Module																																																												
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2016	Tahoe	Chassis	Suspension Control Module																																																												
K	2016	Tahoe	Body	Body Control Module																																																												
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2016	Tahoe	Body	Passenger Presence Module																																																												
K	2016	Tahoe	Body	Instrument Cluster																																																												
K	2016	Tahoe	Body	Radio Controls																																																												
K	2016	Tahoe	Body	HVAC Controls																																																												
K	2016	Tahoe	Body	Radio																																																												
K	2016	Tahoe	Body	Amplifier																																																												
K	2016	Tahoe	Body	Media Disc Player																																																												
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																												
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																												
K	2016	Tahoe	Body	HVAC Control Module																																																												
K	2016	Tahoe	Body	Liftgate Control Module																																																												
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																												
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																												
K	2016	Tahoe	Body	Keyless Entry Control Module																																																												
K	2016	Tahoe	Body	Assist Step Control Module																																																												
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																												
K	2016	Tahoe	Body	Parking Assist Control Module																																																												
K	2016	Tahoe	Body	Frontview Camera Module																																																												
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
L	2004	ALL	Chassis	4WAL 3 Sensor																																																												
L	2004	ALL	Body	Body Control Module																																																											
L	2004	ALL	Body	Instrument Panel Cluster																																																											
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
L	2005	Astro	Chassis	4WAL 3 Sensor																																																											
L	2005	Astro	Body	Body Control Module																																																										
L	2005	Astro	Body	Instrument Panel Cluster																																																										
L	2005	Astro	Body	Supplemental Inflatable Restraint																																																										
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																																										
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																																										
L	2005	Equinox	Chassis	Electric Power Steering																																																										
L	2005	Equinox	Body	Body Control Module																																																										
L	2005	Equinox	Body	Instrument Panel Cluster																																																										
L	2005	Equinox	Body	Radio																																																										
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2006	ALL	Chassis	Traction Control Yes																																																										
L	2006	ALL	Chassis	Traction Control No																																																										
L	2006	ALL	Chassis	Electric Power Steering																																																										
L	2006	ALL	Body	Body Control Module																																																										
L	2006	ALL	Body	Instrument Panel Cluster																																																										
L	2006	ALL	Body	Radio																																																										
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																																										
L	2007	ALL	Chassis	Power Steering Control Module																																																										
L	2007	ALL	Body	Body Control Module																																																										
L	2007	ALL	Body	Digital Radio Receiver																																																										
L	2007	ALL	Body	Heated Seat Module																																																										
L	2007	ALL	Body	HVAC Control Module																																																										
L	2007	ALL	Body	Instrument Panel Cluster																																																										
L	2007	ALL	Body	Passenger Presence System																																																										
L	2007	ALL	Body	Radio																																																										
L	2007	ALL	Body	Rollover Sensor																																																										
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Body	Theft Deterrent Module																																																										
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2008	Captiva Sport	Body	Body Control Module																																																										
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2008	Captiva Sport	Body	HVAC Control Module Auto																																																										
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																																										
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2008	Captiva Sport	Body	Passenger Presence System																																																										
L	2008	Captiva Sport	Body	Radio																																																										
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2008	Captiva Sport	Body	Rollover Sensor																																																										
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2008	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2008	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2008	Equinox	Chassis	Power Steering Control Module																																																										
L	2008	Equinox	Body	Body Control Module																																																										
L	2008	Equinox	Body	Digital Radio Receiver																																																										
L	2008	Equinox	Body	Heated Seat Module																																																										
L	2008	Equinox	Body	HVAC Control Module																																																										
L	2008	Equinox	Body	Instrument Panel Cluster																																																										
L	2008	Equinox	Body	Passenger Presence System																																																										
L	2008	Equinox	Body	Radio																																																										
L	2008	Equinox	Body	Rollover Sensor																																																										
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2008	Equinox	Body	Theft Deterrent Module																																																										
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																										
L	2009	Captiva Sport	Body	Body Control Module																																																										
L	2009	Captiva Sport	Body	HVAC Control Module Auto																																																										
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																																										
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2009	Captiva Sport	Body	Passenger Presence System																																																										
L	2009	Captiva Sport	Body	Radio																																																										
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2009	Captiva Sport	Body	Rollover Sensor																																																										
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2009	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																											
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																												
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																												
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
L	2009	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2009	Equinox	Chassis	Power Steering Control Module																																																												
L	2009	Equinox	Body	Body Control Module																																																												
L	2009	Equinox	Body	Digital Radio Receiver																																																												
L	2009	Equinox	Body	Heated Seat Module																																																												
L	2009	Equinox	Body	HVAC Control Module																																																												
L	2009	Equinox	Body	Instrument Panel Cluster																																																												
L	2009	Equinox	Body	Passenger Presence System																																																												
L	2009	Equinox	Body	Radio																																																											
L	2009	Equinox	Body	Rollover Sensor																																																											
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																																											
L	2009	Equinox	Body	Theft Deterrent Module																																																											
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																												
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																												
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																												
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																												
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																												
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																												
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																												
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																												
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																																												
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																												
L	2010	Captiva Sport	Body	Body Control Module																																																												
L	2010	Captiva Sport	Body	HVAC Control Module																																																												
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																																												
L	2010	Captiva Sport	Body	Passenger Presence System																																																												
L	2010	Captiva Sport	Body	Radio																																																												
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2010	Captiva Sport	Body	Rollover Sensor																																																												
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																																												
L	2010	Captiva Sport	Body	Theft Deterrent Module																																																												
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																												
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																												
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																												
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																												
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2010	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2010	Equinox	Body	Body Control Module																																																												
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2010	Equinox	Body	Passenger Presence Module																																																												
L	2010	Equinox	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2010	Equinox	Body	Radio																																																										
L	2010	Equinox	Body	Multimedia Player Interface Module																																																										
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2010	Equinox	Body	Liftgate Control Module																																																										
L	2010	Equinox	Body	Parking Assist Control Module																																																										
L	2010	Equinox	Body	Frontview Camera Module																																																										
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																					V																																					
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
L	2011	Captiva	Chassis	Electronic Brake Control Module																																																										
L	2011	Captiva	Chassis	Parking Brake Control Module																																																										
L	2011	Captiva	Body	Body Control Module																																																										
L	2011	Captiva	Body	Auxiliary Body Control Module																																																										
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2011	Captiva	Body	Instrument Cluster																																																										
L	2011	Captiva	Body	Headlamp Control Module																																																										
L	2011	Captiva	Body	HVAC Control Module																																																										
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																										
L	2011	Captiva	Body	Parking Assist Control Module																					V																																					
L	2011	Captiva	Body	Theft Deterrent Module																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																																										
L	2011	Captiva Sport	Body	Body Control Module																																																										
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2011	Captiva Sport	Body	HVAC Control Module																																																										
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2011	Captiva Sport	Body	Passenger Presence System																																																										
L	2011	Captiva Sport	Body	Radio																																																										
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2011	Captiva Sport	Body	Rollover Sensor																																																										
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2011	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																																										
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																										
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																										
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2011	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2011	Equinox	Body	Body Control Module																																																										
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2011	Equinox	Body	Passenger Presence Module																																																										
L	2011	Equinox	Body	Instrument Cluster																																																										
L	2011	Equinox	Body	Radio																																																										
L	2011	Equinox	Body	Multimedia Player Interface Module																																																										
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2011	Equinox	Body	Liftgate Control Module																																																										
L	2011	Equinox	Body	Parking Assist Control Module																																																										
L	2011	Equinox	Body	Frontview Camera Module																																																										
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																					V																																					
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
L	2012	Captiva	Chassis	Electronic Brake Control Module																																																										
L	2012	Captiva	Chassis	Parking Brake Control Module																																																										
L	2012	Captiva	Body	Body Control Module																																																										
L	2012	Captiva	Body	Auxiliary Body Control Module																																																										
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2012	Captiva	Body	Instrument Cluster																																																										
L	2012	Captiva	Body	Headlamp Control Module																																																										
L	2012	Captiva	Body	HVAC Control Module																																																										
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																										
L	2012	Captiva	Body	Parking Assist Control Module																				V																																						
L	2012	Captiva	Body	Theft Deterrent Module																																																										
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																										
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																										
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																										
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																										
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																										
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																										
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																										
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																																										
L	2012	Captiva Sport	Body	Body Control Module																																																										
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2012	Captiva Sport	Body	HVAC Control Module																																																										
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2012	Captiva Sport	Body	Passenger Presence System																																																										
L	2012	Captiva Sport	Body	Radio																																																										
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2012	Captiva Sport	Body	Rollover Sensor																																																										
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2012	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																										
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2012	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2012	Equinox	Body	Body Control Module																																																										
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2012	Equinox	Body	Passenger Presence Module																																																										
L	2012	Equinox	Body	Instrument Cluster																																																										
L	2012	Equinox	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2012	Equinox	Body	Multimedia Player Interface Module																																																											
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											
L	2012	Equinox	Body	Liftgate Control Module																																																											
L	2012	Equinox	Body	Parking Assist Control Module																																																											
L	2012	Equinox	Body	Frontview Camera Module																																																											
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																					V																																						
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																											
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																											
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																											
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																											
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																											
L	2013	Captiva	Chassis	Parking Brake Control Module																																																											
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																											
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																											
L	2013	Captiva	Body	Auxiliary Body Control Module																																																											
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2013	Captiva	Body	Instrument Cluster																																																											
L	2013	Captiva	Body	Headlamp Control Module																																																											
L	2013	Captiva	Body	HVAC Control Module																																																											
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
L	2013	Captiva	Body	Theft Deterrent Module																																																											
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																											
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																											
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																											
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																											
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																											
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																											
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																																											
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																											
L	2013	Captiva Sport	Body	Body Control Module																																																											
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																											
L	2013	Captiva Sport	Body	Heated Seat Module																																																											
L	2013	Captiva Sport	Body	HVAC Control Module																																																											
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2013	Captiva Sport	Body	Park Assist Module																																																											
L	2013	Captiva Sport	Body	Passenger Presence System																																																												
L	2013	Captiva Sport	Body	Radio																																																												
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																																												
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																												
L	2013	Captiva Sport	Body	Theft Deterrent Module																																																												
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2013	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2013	Equinox	Chassis	Power Steering Control Module																																																												
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																												
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2013	Equinox	Body	Passenger Presence Module																																																												
L	2013	Equinox	Body	Instrument Cluster																																																												
L	2013	Equinox	Body	Radio																																																												
L	2013	Equinox	Body	Rear Audio Control Module																																																												
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2013	Equinox	Body	Liftgate Control Module																																																												
L	2013	Equinox	Body	Front Seat Heating Control Module																																																												
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																												
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																												
L	2013	Equinox	Body	Parking Assist Control Module																																																												
L	2013	Equinox	Body	Frontview Camera Module																																																												
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																												
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																												
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																												
L	2014	Captiva (3GN)	Body	Body Control Module																																																												
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																												
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																												
L	2014	Captiva (3GN)	Body	Radio																																																												
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																												
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																												
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																				V																																								
L	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																												
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																												
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																												
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																												
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																												
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																												
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																												
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																												
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																												
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																												
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																												
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2014	Captiva (Other)	Body	Instrument Cluster																																																												
L	2014	Captiva (Other)	Body	Headlamp Control Module																																																												
L	2014	Captiva (Other)	Body	HVAC Control Module																																																												
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																												
L	2014	Captiva (Other)	Body	Theft Deterrent Module																																																												
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2014	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2014	Equinox	Chassis	Power Steering Control Module																																																												
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																												
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2014	Equinox	Body	Passenger Presence Module																																																												
L	2014	Equinox	Body	Instrument Cluster																																																												
L	2014	Equinox	Body	Radio																																																											
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2014	Equinox	Body	Liftgate Control Module																																																											
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																												
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																												
L	2014	Equinox	Body	Parking Assist Control Module																																																												
L	2014	Equinox	Body	Frontview Camera Module																																																												
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																												
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																												
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																												
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																												
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																												
L	2015	Captiva (3GN)	Body	Body Control Module																																																												
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																																												
L	2015	Captiva (3GN)	Body	Instrument Cluster																																																												
L	2015	Captiva (3GN)	Body	Radio																																																												
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																												
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																												
L	2015	Captiva (3GN)	Body	HVAC Control Module																																																												
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																				V																																								
L	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																												
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																												
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																												
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																												
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																												
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																												
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																												
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																												
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																												
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																												
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2015	Captiva (Other)	Body	Instrument Cluster																																																												
L	2015	Captiva (Other)	Body	Headlamp Control Module																																																												
L	2015	Captiva (Other)	Body	HVAC Control Module																																																												
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
L	2015	Captiva (Other)	Body	Theft Deterrent Module																																																												
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2015	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2015	Equinox	Chassis	Power Steering Control Module																																																												
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																																												
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2015	Equinox	Body	Passenger Presence Module																																																												
L	2015	Equinox	Body	Instrument Cluster																																																												
L	2015	Equinox	Body	Radio																																																											
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																																											
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											
L	2015	Equinox	Body	Liftgate Control Module																																																											
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																											
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																											
L	2015	Equinox	Body	Parking Assist Control Module																																																											
L	2015	Equinox	Body	Frontview Camera Module																																																											
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																											
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																											
L	2016	Captiva (3GN)	Body	Body Control Module																																																											
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2016	Captiva (3GN)	Body	Instrument Cluster																																																											
L	2016	Captiva (3GN)	Body	Radio																																																											
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																											
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																											
L	2016	Captiva (3GN)	Body	HVAC Control Module																																																											
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																											
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																											
L	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Captiva (Other)	Body	Instrument Cluster																																																										
L	2016	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2016	Captiva (Other)	Body	Radio																																																										
L	2016	Captiva (Other)	Body	HVAC Control Module																																																										
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2016	Captiva (Other)	Body	Theft Deterrent Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2016	Equinox	Chassis	Power Steering Control Module																																																										
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Equinox	Body	Passenger Presence Module																																																										
L	2016	Equinox	Body	Instrument Cluster																																																										
L	2016	Equinox	Body	Radio																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2016	Equinox	Body	Liftgate Control Module																																																										
L	2016	Equinox	Body	Seat Memory Control Module																																																										
L	2016	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Parking Assist Control Module																																																										
L	2016	Equinox	Body	Frontview Camera Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
M	2004	ALL	Chassis	4WAL 3 Sensor																																																											
M	2004	ALL	Body	Body Control Module																																																											
M	2004	ALL	Body	Instrument Panel Cluster																																																											
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
M	2005	ALL	Chassis	4WAL 3 Sensor																																																											
M	2005	ALL	Body	Body Control Module																																																											
M	2005	ALL	Body	Instrument Panel Cluster																																																											
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
P	2007	ALL	Body	Theft Deterrent Module																																																											
R	2009	ALL	Powertrain	Engine Control Module																																																											
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2009	ALL	Powertrain	Transmission Control Module																																																											
R	2009	ALL	Chassis	Electronic Brake Control Module																																																											
R	2009	ALL	Body	Body Control Module																																																											
R	2009	ALL	Body	Digital Radio Receiver																																																											
R	2009	ALL	Body	Driver Door Switch																																																											
R	2009	ALL	Body	Heated Seat Module																																																											
R	2009	ALL	Body	HVAC Control Module Auto																																																											
R	2009	ALL	Body	HVAC Control Module Manual																																																											
R	2009	ALL	Body	Instrument Panel Cluster																																																											
R	2009	ALL	Body	Lift Gate Module																																																											
R	2009	ALL	Body	Park Assist Module																																																											
R	2009	ALL	Body	Passenger Door Switch																																																											
R	2009	ALL	Body	Passenger Presence System																																																											
R	2009	ALL	Body	Radio																																																											
R	2009	ALL	Body	Rear HVAC/RSA																																																											
R	2009	ALL	Body	Rollover Sensor																																																											
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2009	ALL	Body	Theft Deterrent Module																																																											
R	2010	ALL	Powertrain	Engine Control Module																																																											
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2010	ALL	Powertrain	Transmission Control Module																																																											
R	2010	ALL	Chassis	Electronic Brake Control Module																																																											
R	2010	ALL	Body	Body Control Module																																																											
R	2010	ALL	Body	Digital Radio Receiver																																																											
R	2010	ALL	Body	Driver Door Switch																																																											
R	2010	ALL	Body	Heated Seat Module																																																											
R	2010	ALL	Body	HVAC Control Module Auto																																																											
R	2010	ALL	Body	HVAC Control Module Manual																																																											
R	2010	ALL	Body	Instrument Panel Cluster																																																											
R	2010	ALL	Body	Lift Gate Module																																																											
R	2010	ALL	Body	Park Assist Module																																																											
R	2010	ALL	Body	Passenger Door Switch																																																											
R	2010	ALL	Body	Passenger Presence System																																																											
R	2010	ALL	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2010	ALL	Body	Rear HVAC/RSA																																																										
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2010	ALL	Body	Theft Deterrent Module																																																										
R	2011	ALL	Powertrain	Engine Control Module																																																										
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2011	ALL	Powertrain	Transmission Control Module																																																										
R	2011	ALL	Chassis	Electronic Brake Control Module																																																										
R	2011	ALL	Body	Body Control Module																																																										
R	2011	ALL	Body	Digital Radio Receiver																																																										
R	2011	ALL	Body	Driver Door Switch																																																										
R	2011	ALL	Body	Heated Seat Module																																																										
R	2011	ALL	Body	HVAC Control Module Auto																																																										
R	2011	ALL	Body	HVAC Control Module Manual																																																										
R	2011	ALL	Body	Instrument Panel Cluster																																																										
R	2011	ALL	Body	Lift Gate Module																																																										
R	2011	ALL	Body	Park Assist Module																																																										
R	2011	ALL	Body	Passenger Door Switch																																																										
R	2011	ALL	Body	Passenger Presence System																																																										
R	2011	ALL	Body	Radio																																																										
R	2011	ALL	Body	Rear HVAC/RSA																																																										
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2011	ALL	Body	Theft Deterrent Module																																																										
R	2012	ALL	Powertrain	Engine Control Module																																																										
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2012	ALL	Powertrain	Transmission Control Module																																																										
R	2012	ALL	Chassis	Electronic Brake Control Module																																																										
R	2012	ALL	Body	Body Control Module																																																										
R	2012	ALL	Body	Digital Radio Receiver																																																										
R	2012	ALL	Body	Driver Door Switch																																																										
R	2012	ALL	Body	Heated Seat Module																																																										
R	2012	ALL	Body	HVAC Control Module Auto																																																										
R	2012	ALL	Body	HVAC Control Module Manual																																																										
R	2012	ALL	Body	Instrument Panel Cluster																																																										
R	2012	ALL	Body	Lift Gate Module																																																										
R	2012	ALL	Body	Park Assist Module																																																										
R	2012	ALL	Body	Passenger Door Switch																																																										
R	2012	ALL	Body	Passenger Presence System																																																										
R	2012	ALL	Body	Radio																																																										
R	2012	ALL	Body	Rear HVAC/RSA																																																										
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2012	ALL	Body	Theft Deterrent Module																																																										
R	2013	ALL	Powertrain	Engine Control Module																																																										
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2013	ALL	Powertrain	Transmission Control Module																																																										
R	2013	ALL	Chassis	Electronic Brake Control Module																																																										
R	2013	ALL	Body	Body Control Module																																																										
R	2013	ALL	Body	Digital Radio Receiver																																																										
R	2013	ALL	Body	Driver Door Switch																																																										
R	2013	ALL	Body	Heated Seat Module																																																										
R	2013	ALL	Body	HVAC Control Module Auto																																																										
R	2013	ALL	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2013	ALL	Body	Instrument Panel Cluster																																																											
R	2013	ALL	Body	Left Side Object Detection Module																																																												
R	2013	ALL	Body	Lift Gate Module																																																												
R	2013	ALL	Body	Park Assist Module																																																												
R	2013	ALL	Body	Passenger Door Switch																																																												
R	2013	ALL	Body	Passenger Presence System																																																												
R	2013	ALL	Body	Radio																																																												
R	2013	ALL	Body	Rear HVAC/RSA																																																												
R	2013	ALL	Body	Right Side Object Detection Module																																																												
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2013	ALL	Body	Theft Deterrent Module																																																												
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2014	Traverse	Powertrain	Chassis Control Module																																																												
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
R	2014	Traverse	Chassis	Electronic Brake Control Module																																																												
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																												
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Traverse	Body	Passenger Presence Module																																																												
R	2014	Traverse	Body	Instrument Cluster																																																												
R	2014	Traverse	Body	Radio																																																												
R	2014	Traverse	Body	Rear Audio Control Module																																																												
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																												
R	2014	Traverse	Body	Personal Audio Link Control Module																																																												
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																											V																																	
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																											V																																	
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																												
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																												
R	2014	Traverse	Body	Liftgate Control Module																																																												
R	2014	Traverse	Body	Seat Memory Control Module																																																												
R	2014	Traverse	Body	Front Seat Heating Control Module																																																												
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																												
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																												
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																												
R	2014	Traverse	Body	Parking Assist Control Module																																																												
R	2014	Traverse	Body	Frontview Camera Module																																																												
R	2014	Traverse	Body	Theft Deterrent Module																																																												
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
R	2015	Traverse	Chassis	Electronic Brake Control Module																																																												
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																												
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																											
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2015	Traverse	Body	Passenger Presence Module																																																											
R	2015	Traverse	Body	Instrument Cluster																																																											
R	2015	Traverse	Body	Radio																																																											
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																												V																														
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																												V																														
R	2015	Traverse	Body	Liftgate Control Module																																																										
R	2015	Traverse	Body	Seat Memory Control Module																																																										
R	2015	Traverse	Body	Front Seat Heating Control Module																																																										
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2015	Traverse	Body	Parking Assist Control Module																																																										
R	2015	Traverse	Body	Frontview Camera Module																																																										
R	2015	Traverse	Body	Theft Deterrent Module																																																										
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2016	Traverse	Chassis	Electronic Brake Control Module																																																										
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Traverse	Body	Passenger Presence Module																																																										
R	2016	Traverse	Body	Instrument Cluster																																																										
R	2016	Traverse	Body	Radio																																																										
R	2016	Traverse	Body	Rear Audio Control Module																																																										
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																										
R	2016	Traverse	Body	Personal Audio Link Control Module																																																										
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																										
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																												V																														
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																												V																														
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Traverse	Body	Liftgate Control Module																																																										
R	2016	Traverse	Body	Seat Memory Control Module																																																										
R	2016	Traverse	Body	Front Seat Heating Control Module																																																										
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2016	Traverse	Body	Parking Assist Control Module																																																										
R	2016	Traverse	Body	Frontview Camera Module																																																										
R	2016	Traverse	Body	Theft Deterrent Module																																																										
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	S10	Chassis	4WAL 3 Sensor																																																										
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																										
S	2004	S10	Body	Body Control Module																																																										
S	2004	S10	Body	Instrument Panel Cluster																																																										
S	2004	S10	Body	Base Radio																																																										
S	2004	S10	Body	Uplevel Radio																																																										
S	2004	S10	Body	Supplemental Inflatable Restraint																																																										
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
S	2004	Colorado	Chassis	ABS Without Traction Control																																																												
S	2004	Colorado	Chassis	ABS With Traction Control																																																												
S	2004	Colorado	Body	Body Control Module																																																												
S	2004	Colorado	Body	Instrument Panel Cluster																																																												
S	2004	Colorado	Body	OnStar																																																												
S	2004	Colorado	Body	Base Radio																																																												
S	2004	Colorado	Body	Uplevel Radio																																																												
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																												
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																												
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																												
S	2004	TrailBlazer	Body	Body Control Module																																																												
S	2004	TrailBlazer	Body	Driver Door Module																																																												
S	2004	TrailBlazer	Body	Driver Seat Module																																																												
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																												
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																												
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2004	TrailBlazer	Body	Lift Gate Module																																																												
S	2004	TrailBlazer	Body	OnStar																																																												
S	2004	TrailBlazer	Body	Passenger Door Module																																																												
S	2004	TrailBlazer	Body	Uplevel Radio																																																												
S	2004	TrailBlazer	Body	Navigation Radio																																																												
S	2004	TrailBlazer	Body	Rear Seat Audio																																																												
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																												
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																												
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																												
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																												
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																												
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																												
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																												
S	2004	TrailBlazer EXT	Body	Body Control Module																																																												
S	2004	TrailBlazer EXT	Body	Driver Door Module																																																												
S	2004	TrailBlazer EXT	Body	Driver Seat Module																																																												
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																												
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																												
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																												
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																												
S	2004	TrailBlazer EXT	Body	OnStar																																																												
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																																												
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																												
S	2004	TrailBlazer EXT	Body	Navigation Radio																																																												
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																												
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																												
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																												
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																												
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																												
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																												
S	2004	Blazer	Body	Body Control Module																																																												
S	2004	Blazer	Body	Heating and Air Conditioning																																																												
S	2004	Blazer	Body	Instrument Panel Cluster																																																												
S	2004	Blazer	Body	Memory Seat Module																																																												
S	2004	Blazer	Body	Base Radio																																																												
S	2004	Blazer	Body	Uplevel Radio																																																												
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																																												
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																												
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																												
S	2004	SSR	Chassis	4WAL 3 Sensor																																																												
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																												
S	2004	SSR	Body	Amplifier (Bose)																																																												
S	2004	SSR	Body	Body Control Module																																																												
S	2004	SSR	Body	Driver Seat Module																																																												
S	2004	SSR	Body	Instrument Panel Cluster																																																												
S	2004	SSR	Body	Uplevel Radio																																																												
S	2004	SSR	Body	Remote Function Actuation																																																												
S	2004	SSR	Body	Roof and Door Module																																																												
S	2004	SSR	Body	Supplemental Inflatable Restraint																																																												
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
S	2005	Colorado	Chassis	ABS Without Traction Control																																																												
S	2005	Colorado	Chassis	ABS With Traction Control																																																												
S	2005	Colorado	Body	Body Control Module																																																												
S	2005	Colorado	Body	Instrument Panel Cluster																																																												
S	2005	Colorado	Body	Base Radio																																																												
S	2005	Colorado	Body	Uplevel Radio																																																												
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																																												
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																												
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																												
S	2005	TrailBlazer	Body	Body Control Module																																																												
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																												
S	2005	TrailBlazer	Body	Driver Door Module																																																												
S	2005	TrailBlazer	Body	Driver Seat Module																																																												
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																												
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																												
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2005	TrailBlazer	Body	Lift Gate Module																																																											
S	2005	TrailBlazer	Body	Passenger Door Module																																																												
S	2005	TrailBlazer	Body	Passenger Presence System																																																												
S	2005	TrailBlazer	Body	Uplevel Radio																																																												
S	2005	TrailBlazer	Body	Navigation Radio																																																												
S	2005	TrailBlazer	Body	Rear Seat Audio																																																												
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																												
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																												
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																												
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																												
S	2005	TrailBlazer EXT	Body	Body Control Module																																																												
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																												
S	2005	TrailBlazer EXT	Body	Driver Door Module																																																												
S	2005	TrailBlazer EXT	Body	Driver Seat Module																																																												
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																												
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																												
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																												
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																												
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																																												
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																												
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																												
S	2005	TrailBlazer EXT	Body	Navigation Radio																																																												
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																												
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																												
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																												
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																												
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																												
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																												
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																												
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																												
S	2005	Blazer	Body	Body Control Module																																																												
S	2005	Blazer	Body	Heating and Air Conditioning																																																												
S	2005	Blazer	Body	Instrument Panel Cluster																																																												
S	2005	Blazer	Body	Memory Seat Module																																																												
S	2005	Blazer	Body	Base Radio																																																												
S	2005	Blazer	Body	Uplevel Radio																																																												
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																																												
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2005	SSR	Chassis	4WAL 3 Sensor																																																												
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																												
S	2005	SSR	Body	Amplifier (Bose)																																																												
S	2005	SSR	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2005	SSR	Body	Driver Seat Module																																																											
S	2005	SSR	Body	Instrument Panel Cluster																																																												
S	2005	SSR	Body	Uplevel Radio																																																												
S	2005	SSR	Body	Remote Function Actuation																																																												
S	2005	SSR	Body	Roof and Door Module																																																												
S	2005	SSR	Body	Supplemental Inflatable Restraint																																																												
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
S	2006	Colorado	Chassis	ABS Without Traction Control																																																												
S	2006	Colorado	Chassis	ABS With Traction Control																																																												
S	2006	Colorado	Body	Body Control Module																																																												
S	2006	Colorado	Body	Instrument Panel Cluster																																																												
S	2006	Colorado	Body	Passenger Presence System																																																												
S	2006	Colorado	Body	Base Radio																																																												
S	2006	Colorado	Body	Uplevel Radio																																																												
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																																												
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																												
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																												
S	2006	TrailBlazer	Body	Body Control Module																																																												
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																												
S	2006	TrailBlazer	Body	Driver Door Module																																																												
S	2006	TrailBlazer	Body	Driver Seat Module																																																												
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																												
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																												
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2006	TrailBlazer	Body	Lift Gate Module																																																												
S	2006	TrailBlazer	Body	Passenger Door Module																																																												
S	2006	TrailBlazer	Body	Passenger Presence System																																																												
S	2006	TrailBlazer	Body	Uplevel Radio																																																												
S	2006	TrailBlazer	Body	Navigation Radio																																																												
S	2006	TrailBlazer	Body	Rear Seat Audio																																																												
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																												
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																												
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																												
S	2006	TrailBlazer EXT	Body	Body Control Module																																																												
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																												
S	2006	TrailBlazer EXT	Body	Driver Door Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2006	TrailBlazer EXT	Body	Driver Seat Module																																																												
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																												
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																												
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																												
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																												
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																																												
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																												
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																												
S	2006	TrailBlazer EXT	Body	Navigation Radio																																																												
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																												
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																												
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																												
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																												
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																												
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																												
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2006	SSR	Chassis	4WAL 3 Sensor																																																												
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																												
S	2006	SSR	Body	Amplifier (Bose)																																																												
S	2006	SSR	Body	Body Control Module																																																												
S	2006	SSR	Body	Driver Seat Module																																																												
S	2006	SSR	Body	Instrument Panel Cluster																																																												
S	2006	SSR	Body	Uplevel Radio																																																												
S	2006	SSR	Body	Remote Function Actuation																																																												
S	2006	SSR	Body	Roof and Door Module																																																												
S	2006	SSR	Body	Supplemental Inflatable Restraint																																																												
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2007	Colorado	Body	Body Control Module																																																												
S	2007	Colorado	Body	Digital Radio Receiver																																																												
S	2007	Colorado	Body	Generator Battery Control Module																																																												
S	2007	Colorado	Body	Instrument Panel Cluster																																																												
S	2007	Colorado	Body	Passenger Presence System																																																												
S	2007	Colorado	Body	Base Radio																																																												
S	2007	Colorado	Body	Uplevel Radio																																																												
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																																												
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																												
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																												
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2007	Trailblazer	Body	Body Control Module																																																											
S	2007	Trailblazer	Body	Digital Radio Receiver																																																												
S	2007	Trailblazer	Body	Disc Player and Video Display																																																												
S	2007	Trailblazer	Body	Driver Door Module																																																												
S	2007	Trailblazer	Body	Driver Seat Module																																																												
S	2007	Trailblazer	Body	Generator Battery Control Module																																																												
S	2007	Trailblazer	Body	HVAC Control Module Auto																																																												
S	2007	Trailblazer	Body	HVAC Control Module Manual																																																												
S	2007	Trailblazer	Body	Instrument Panel Cluster																																																												
S	2007	Trailblazer	Body	Lift Gate Module																																																												
S	2007	Trailblazer	Body	Passenger Door Module																																																												
S	2007	Trailblazer	Body	Passenger Presence System																																																												
S	2007	Trailblazer	Body	Uplevel Radio																																																												
S	2007	Trailblazer	Body	Navigation Radio																																																												
S	2007	Trailblazer	Body	Rear Seat Audio																																																												
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																												
S	2007	Trailblazer	Body	Theft Deterrent Module																																																												
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																												
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2008	Colorado	Body	Body Control Module																																																												
S	2008	Colorado	Body	Digital Radio Receiver																																																												
S	2008	Colorado	Body	Generator Battery Control Module																																																												
S	2008	Colorado	Body	Instrument Panel Cluster																																																												
S	2008	Colorado	Body	Passenger Presence System																																																												
S	2008	Colorado	Body	Base Radio																																																												
S	2008	Colorado	Body	Uplevel Radio																																																												
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2008	Colorado	Body	Theft Deterrent Module																																																												
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																																												
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
S	2008	TrailBlazer	Body	Body Control Module																																																												
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																												
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																												
S	2008	TrailBlazer	Body	Driver Door Module																																																												
S	2008	TrailBlazer	Body	Driver Seat Module																																																												
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																												
S	2008	TrailBlazer	Body	HVAC Control Module Auto																																																												
S	2008	TrailBlazer	Body	HVAC Control Module Manual																																																												
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2008	TrailBlazer	Body	Lift Gate Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2008	TrailBlazer	Body	Passenger Door Module																																																											
S	2008	TrailBlazer	Body	Passenger Presence System																																																												
S	2008	TrailBlazer	Body	Uplevel Radio																																																												
S	2008	TrailBlazer	Body	Navigation Radio																																																												
S	2008	TrailBlazer	Body	Rear Seat Audio																																																												
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
S	2008	TrailBlazer	Body	Theft Deterrent Module																																																												
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																												
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																												
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																												
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																												
S	2009	Colorado	Chassis	Electronic Brake Control Module																																																												
S	2009	Colorado	Body	Body Control Module																																																												
S	2009	Colorado	Body	Digital Radio Receiver																																																												
S	2009	Colorado	Body	Generator Battery Control Module																																																												
S	2009	Colorado	Body	Instrument Panel Cluster																																																												
S	2009	Colorado	Body	Passenger Presence System																																																												
S	2009	Colorado	Body	Base Radio																																																												
S	2009	Colorado	Body	Uplevel Radio																																																												
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2009	Colorado	Body	Theft Deterrent Module																																																												
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																												
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																												
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
S	2009	TrailBlazer	Body	Body Control Module																																																												
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																												
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																												
S	2009	TrailBlazer	Body	Driver Door Module																																																												
S	2009	TrailBlazer	Body	Driver Seat Module																																																												
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																												
S	2009	TrailBlazer	Body	HVAC Control Module Auto																																																												
S	2009	TrailBlazer	Body	HVAC Control Module Manual																																																												
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2009	TrailBlazer	Body	Lift Gate Module																																																												
S	2009	TrailBlazer	Body	Passenger Door Module																																																												
S	2009	TrailBlazer	Body	Passenger Presence System																																																												
S	2009	TrailBlazer	Body	Uplevel Radio																																																												
S	2009	TrailBlazer	Body	Navigation Radio																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2009	TrailBlazer	Body	Rear Seat Audio																																																										
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2009	TrailBlazer	Body	Theft Deterrent Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2010	ALL	Chassis	Electronic Brake Control Module																																																										
S	2010	ALL	Body	Body Control Module																																																										
S	2010	ALL	Body	Digital Radio Receiver																																																										
S	2010	ALL	Body	Generator Battery Control Module																																																										
S	2010	ALL	Body	Instrument Panel Cluster																																																										
S	2010	ALL	Body	Passenger Presence System																																																										
S	2010	ALL	Body	Personal Audio Link Module																																																										
S	2010	ALL	Body	Base Radio																																																										
S	2010	ALL	Body	Uplevel Radio																																																										
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
S	2010	ALL	Body	Theft Deterrent Module																																																										
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																										
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2011	ALL	Chassis	Electronic Brake Control Module																																																										
S	2011	ALL	Body	Body Control Module																																																										
S	2011	ALL	Body	Digital Radio Receiver																																																										
S	2011	ALL	Body	Generator Battery Control Module																																																										
S	2011	ALL	Body	Instrument Panel Cluster																																																										
S	2011	ALL	Body	Passenger Presence System																																																										
S	2011	ALL	Body	Personal Audio Link Module																																																										
S	2011	ALL	Body	Base Radio																																																										
S	2011	ALL	Body	Uplevel Radio																																																										
S	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
S	2011	ALL	Body	Theft Deterrent Module																																																										
S	2011	ALL	Body	Vehicle Comm. Interface Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																										
S	2012	Colorado (First Gen)	Body	Body Control Module																																																										
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																										
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																										
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																										
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																										
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																										
S	2012	Colorado (First Gen)	Body	Base Radio																																																										
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																										
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																										
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																										
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																										
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																										
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2012	Colorado (Second Gen)	Body	Body Control Module																																																										
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																										
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																										
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2012	S10	Powertrain	Transfer Case Control Module																																																										
S	2012	S10	Chassis	Electronic Brake Control Module																																																										
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2012	S10	Body	Body Control Module																																																										
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	S10	Body	Instrument Cluster																																																										
S	2012	S10	Body	Trailer Interface Control Module																																																										
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																											
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																											
S	2013	Colorado	Powertrain	Transfer Case Control Module																																																											
S	2013	Colorado	Chassis	Electronic Brake Control Module																																																											
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2013	Colorado	Body	Body Control Module																																																											
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2013	Colorado	Body	Instrument Cluster																																																											
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																											
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																											
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																											
S	2013	S10	Powertrain	Transfer Case Control Module																																																											
S	2013	S10	Chassis	Electronic Brake Control Module																																																											
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2013	S10	Body	Body Control Module																																																											
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2013	S10	Body	Instrument Cluster																																																											
S	2013	S10	Body	Trailer Interface Control Module																																																											
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																											
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																											
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																											
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																											
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2013	Trailblazer	Body	Body Control Module																																																											
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2013	Trailblazer	Body	Instrument Cluster																																																											
S	2013	Trailblazer	Body	Trailer Interface Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2013	Trailblazer	Body	Parking Assist Control Module																																																											
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																												
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																												
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																												
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2014	Colorado	Body	Body Control Module																																																												
S	2014	Colorado	Body	Body Control Module																																																												
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2014	Colorado	Body	Instrument Cluster																																																												
S	2014	Colorado	Body	Radio																																																											
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																												
S	2014	Colorado	Body	Parking Assist Control Module																																																												
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2014	S10	Powertrain	Transfer Case Control Module																																																												
S	2014	S10	Chassis	Electronic Brake Control Module																																																												
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2014	S10	Body	Body Control Module																																																												
S	2014	S10	Body	Body Control Module																																																												
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2014	S10	Body	Instrument Cluster																																																												
S	2014	S10	Body	Trailer Interface Control Module																																																												
S	2014	S10	Body	Radio																																																											
S	2014	S10	Body	Parking Assist Control Module																																																												
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																												
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																											
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2014	Trailblazer	Body	Body Control Module																																																												
S	2014	Trailblazer	Body	Body Control Module																																																												
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2014	Trailblazer	Body	Instrument Cluster																																																												
S	2014	Trailblazer	Body	Trailer Interface Control Module																																																												
S	2014	Trailblazer	Body	Parking Assist Control Module																																																												
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
S	2015	Colorado	Powertrain	Chassis Control Module																																																													
S	2015	Colorado	Powertrain	Transfer Case Control Module																																																												
S	2015	Colorado	Chassis	Electronic Brake Control Module																																																												
S	2015	Colorado	Chassis	Power Steering Control Module																																																												
S	2015	Colorado	Body	Body Control Module																																																												
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2015	Colorado	Body	Passenger Presence Module																																																												
S	2015	Colorado	Body	Radio																																																											
S	2015	Colorado	Body	Amplifier																																																											
S	2015	Colorado	Body	Human Machine Interface Control Module																																																											
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																																											
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																											
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																											
S	2015	Colorado	Body	Frontview Camera Module																																																											
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																											
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																											
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																											
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2015	Colorado (MMM)	Body	Body Control Module																																																											
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2015	Colorado (MMM)	Body	Instrument Cluster																																																												
S	2015	Colorado (MMM)	Body	Radio																																																													
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																													
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																													
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																													
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																													
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																													
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																													
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																													
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																													
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																													
S	2015	S10	Powertrain	Transfer Case Control Module																																																													
S	2015	S10	Chassis	Electronic Brake Control Module																																																													
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																													
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																													
S	2015	S10	Body	Body Control Module																																																													
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2015	S10	Body	Instrument Cluster																																																													
S	2015	S10	Body	Trailer Interface Control Module																																																													
S	2015	S10	Body	Radio																																																													
S	2015	S10	Body	Telematics Communication Interface Control Module																																																													
S	2015	S10	Body	Parking Assist Control Module																																																													
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																													
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																													
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																													
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																													
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																													
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																													
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																													
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																													
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																													
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																													
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																													
S	2015	Trailblazer	Body	Body Control Module																																																													
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2015	Trailblazer	Body	Instrument Cluster																																																													
S	2015	Trailblazer	Body	Trailer Interface Control Module																																																													
S	2015	Trailblazer	Body	Radio																																																													
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																													
S	2015	Trailblazer	Body	Parking Assist Control Module																																																													
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																													
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																													
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																										
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																										
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																										
S	2016	Colorado (1GC)	Body	Body Control Module																																																										
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																																										
S	2016	Colorado (1GC)	Body	Radio Controls																																																										
S	2016	Colorado (1GC)	Body	HVAC Controls																																																										
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																										
S	2016	Colorado (1GC)	Body	Radio																																																										
S	2016	Colorado (1GC)	Body	Amplifier																																																										
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																										
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																										
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																										
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																										
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																																										
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																										
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																										
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	Colorado (MMM)	Body	Body Control Module																																																										
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Colorado (MMM)	Body	Instrument Cluster																																																										
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																										
S	2016	Colorado (MMM)	Body	Radio																																																										
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																										
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																										
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																										
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																										
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	S10	Powertrain	Transfer Case Control Module																																																										
S	2016	S10	Chassis	Electronic Brake Control Module																																																										
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	S10	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2016	S10	Body	Instrument Cluster																																																												
S	2016	S10	Body	Trailer Interface Control Module																																																												
S	2016	S10	Body	Radio																																																												
S	2016	S10	Body	Telematics Communication Interface Control Module																																																												
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																												
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																												
S	2016	S10	Body	Parking Assist Control Module																																																												
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																												
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																												
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2016	Trailblazer	Body	Body Control Module																																																												
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2016	Trailblazer	Body	Instrument Cluster																																																												
S	2016	Trailblazer	Body	Trailer Interface Control Module																																																												
S	2016	Trailblazer	Body	Radio																																																												
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																												
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																												
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																												
S	2016	Trailblazer	Body	Parking Assist Control Module																																																												
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2004	S10	Chassis	4WAL 3 Sensor																																																												
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																												
T	2004	S10	Body	Body Control Module																																																												
T	2004	S10	Body	Instrument Panel Cluster																																																												
T	2004	S10	Body	Base Radio																																																												
T	2004	S10	Body	Uplevel Radio																																																												
T	2004	S10	Body	Supplemental Inflatable Restraint																																																												
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2004	Colorado	Chassis	ABS Without Traction Control																																																												
T	2004	Colorado	Chassis	ABS With Traction Control																																																												
T	2004	Colorado	Body	Body Control Module																																																												
T	2004	Colorado	Body	Instrument Panel Cluster																																																												
T	2004	Colorado	Body	OnStar																																																											
T	2004	Colorado	Body	Base Radio																																																											
T	2004	Colorado	Body	Uplevel Radio																																																											
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																																											
T	2004	Colorado	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer	Body	Body Control Module																																																										
T	2004	TrailBlazer	Body	Driver Door Module																																																										
T	2004	TrailBlazer	Body	Driver Seat Module																																																										
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2004	TrailBlazer	Body	Lift Gate Module																																																										
T	2004	TrailBlazer	Body	OnStar																																																										
T	2004	TrailBlazer	Body	Passenger Door Module																																																										
T	2004	TrailBlazer	Body	Uplevel Radio																																																										
T	2004	TrailBlazer	Body	Navigation Radio																																																										
T	2004	TrailBlazer	Body	Rear Seat Audio																																																										
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer EXT	Body	Body Control Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Seat Module																																																										
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2004	TrailBlazer EXT	Body	OnStar																																																										
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2004	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																										
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Blazer	Body	Body Control Module																																																										
T	2004	Blazer	Body	Heating and Air Conditioning																																																										
T	2004	Blazer	Body	Instrument Panel Cluster																																																										
T	2004	Blazer	Body	Memory Seat Module																																																										
T	2004	Blazer	Body	Base Radio																																																										
T	2004	Blazer	Body	Uplevel Radio																																																										
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																																										
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2005	Colorado	Chassis	ABS Without Traction Control																																																										
T	2005	Colorado	Chassis	ABS With Traction Control																																																										
T	2005	Colorado	Body	Body Control Module																																																										
T	2005	Colorado	Body	Instrument Panel Cluster																																																										
T	2005	Colorado	Body	Base Radio																																																										
T	2005	Colorado	Body	Uplevel Radio																																																										
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																										
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
T	2005	TrailBlazer	Body	Body Control Module																																																										
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2005	TrailBlazer	Body	Driver Door Module																																																										
T	2005	TrailBlazer	Body	Driver Seat Module																																																										
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2005	TrailBlazer	Body	Lift Gate Module																																																										
T	2005	TrailBlazer	Body	Passenger Door Module																																																										
T	2005	TrailBlazer	Body	Passenger Presence System																																																										
T	2005	TrailBlazer	Body	Uplevel Radio																																																										
T	2005	TrailBlazer	Body	Navigation Radio																																																										
T	2005	TrailBlazer	Body	Rear Seat Audio																																																										
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
T	2005	TrailBlazer EXT	Body	Body Control Module																																																										
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
T	2005	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2005	TrailBlazer EXT	Body	Driver Seat Module																																																										
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																										
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2005	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																										
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																										
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																										
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Blazer	Body	Body Control Module																																																										
T	2005	Blazer	Body	Heating and Air Conditioning																																																										
T	2005	Blazer	Body	Instrument Panel Cluster																																																										
T	2005	Blazer	Body	Memory Seat Module																																																										
T	2005	Blazer	Body	Base Radio																																																										
T	2005	Blazer	Body	Uplevel Radio																																																										
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																																										
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2006	Colorado	Chassis	ABS Without Traction Control																																																										
T	2006	Colorado	Chassis	ABS With Traction Control																																																										
T	2006	Colorado	Body	Body Control Module																																																										
T	2006	Colorado	Body	Instrument Panel Cluster																																																										
T	2006	Colorado	Body	Passenger Presence System																																																										
T	2006	Colorado	Body	Base Radio																																																										
T	2006	Colorado	Body	Uplevel Radio																																																										
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																																										
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																										
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																										
T	2006	TrailBlazer	Body	Body Control Module																																																										
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2006	TrailBlazer	Body	Driver Door Module																																																										
T	2006	TrailBlazer	Body	Driver Seat Module																																																										
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2006	TrailBlazer	Body	Lift Gate Module																																																										
T	2006	TrailBlazer	Body	Passenger Door Module																																																										
T	2006	TrailBlazer	Body	Passenger Presence System																																																										
T	2006	TrailBlazer	Body	Uplevel Radio																																																										
T	2006	TrailBlazer	Body	Navigation Radio																																																										
T	2006	TrailBlazer	Body	Rear Seat Audio																																																										
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																										
T	2006	TrailBlazer EXT	Body	Body Control Module																																																										
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
T	2006	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2006	TrailBlazer EXT	Body	Driver Seat Module																																																										
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																										
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2006	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																										
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																										
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																												
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																												
T	2007	Colorado	Body	Body Control Module																																																												
T	2007	Colorado	Body	Digital Radio Receiver																																																												
T	2007	Colorado	Body	Generator Battery Control Module																																																												
T	2007	Colorado	Body	Instrument Panel Cluster																																																												
T	2007	Colorado	Body	Passenger Presence System																																																												
T	2007	Colorado	Body	Base Radio																																																												
T	2007	Colorado	Body	Uplevel Radio																																																												
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																																												
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																																												
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																												
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																												
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																												
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																												
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																												
T	2007	Trailblazer	Body	Body Control Module																																																												
T	2007	Trailblazer	Body	Digital Radio Receiver																																																												
T	2007	Trailblazer	Body	Disc Player and Video Display																																																												
T	2007	Trailblazer	Body	Driver Door Module																																																												
T	2007	Trailblazer	Body	Driver Seat Module																																																												
T	2007	Trailblazer	Body	Generator Battery Control Module																																																												
T	2007	Trailblazer	Body	HVAC Control Module Auto																																																												
T	2007	Trailblazer	Body	HVAC Control Module Manual																																																												
T	2007	Trailblazer	Body	Instrument Panel Cluster																																																												
T	2007	Trailblazer	Body	Lift Gate Module																																																												
T	2007	Trailblazer	Body	Passenger Door Module																																																												
T	2007	Trailblazer	Body	Passenger Presence System																																																												
T	2007	Trailblazer	Body	Uplevel Radio																																																												
T	2007	Trailblazer	Body	Navigation Radio																																																												
T	2007	Trailblazer	Body	Rear Seat Audio																																																												
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																												
T	2007	Trailblazer	Body	Theft Deterrent Module																																																												
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																												
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																												
T	2008	Colorado	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2008	Colorado	Body	Digital Radio Receiver																																																										
T	2008	Colorado	Body	Generator Battery Control Module																																																										
T	2008	Colorado	Body	Instrument Panel Cluster																																																										
T	2008	Colorado	Body	Passenger Presence System																																																										
T	2008	Colorado	Body	Base Radio																																																										
T	2008	Colorado	Body	Uplevel Radio																																																										
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2008	Colorado	Body	Theft Deterrent Module																																																										
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																																										
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																										
T	2008	TrailBlazer	Body	Body Control Module																																																										
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																										
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2008	TrailBlazer	Body	Driver Door Module																																																										
T	2008	TrailBlazer	Body	Driver Seat Module																																																										
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																										
T	2008	TrailBlazer	Body	HVAC Control Module Auto																																																										
T	2008	TrailBlazer	Body	HVAC Control Module Manual																																																										
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2008	TrailBlazer	Body	Lift Gate Module																																																										
T	2008	TrailBlazer	Body	Passenger Door Module																																																										
T	2008	TrailBlazer	Body	Passenger Presence System																																																										
T	2008	TrailBlazer	Body	Uplevel Radio																																																										
T	2008	TrailBlazer	Body	Navigation Radio																																																										
T	2008	TrailBlazer	Body	Rear Seat Audio																																																										
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2008	TrailBlazer	Body	Theft Deterrent Module																																																										
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																										
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																										
T	2009	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2009	Colorado	Body	Body Control Module																																																										
T	2009	Colorado	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2009	Colorado	Body	Generator Battery Control Module																																																											
T	2009	Colorado	Body	Instrument Panel Cluster																																																												
T	2009	Colorado	Body	Passenger Presence System																																																												
T	2009	Colorado	Body	Base Radio																																																												
T	2009	Colorado	Body	Uplevel Radio																																																												
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																																												
T	2009	Colorado	Body	Theft Deterrent Module																																																												
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
T	2009	TrailBlazer	Body	Body Control Module																																																												
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																												
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																												
T	2009	TrailBlazer	Body	Driver Door Module																																																												
T	2009	TrailBlazer	Body	Driver Seat Module																																																												
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																												
T	2009	TrailBlazer	Body	HVAC Control Module Auto																																																												
T	2009	TrailBlazer	Body	HVAC Control Module Manual																																																												
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																																												
T	2009	TrailBlazer	Body	Lift Gate Module																																																												
T	2009	TrailBlazer	Body	Passenger Door Module																																																												
T	2009	TrailBlazer	Body	Passenger Presence System																																																												
T	2009	TrailBlazer	Body	Uplevel Radio																																																												
T	2009	TrailBlazer	Body	Navigation Radio																																																												
T	2009	TrailBlazer	Body	Rear Seat Audio																																																												
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
T	2009	TrailBlazer	Body	Theft Deterrent Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																												
T	2010	ALL	Chassis	Electronic Brake Control Module																																																												
T	2010	ALL	Body	Body Control Module																																																												
T	2010	ALL	Body	Digital Radio Receiver																																																												
T	2010	ALL	Body	Generator Battery Control Module																																																												
T	2010	ALL	Body	Instrument Panel Cluster																																																												
T	2010	ALL	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2010	ALL	Body	Personal Audio Link Module																																																											
T	2010	ALL	Body	Base Radio																																																											
T	2010	ALL	Body	Uplevel Radio																																																											
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2010	ALL	Body	Theft Deterrent Module																																																											
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																											
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
T	2011	ALL	Chassis	Electronic Brake Control Module																																																											
T	2011	ALL	Body	Body Control Module																																																											
T	2011	ALL	Body	Digital Radio Receiver																																																											
T	2011	ALL	Body	Generator Battery Control Module																																																											
T	2011	ALL	Body	Instrument Panel Cluster																																																											
T	2011	ALL	Body	Passenger Presence System																																																											
T	2011	ALL	Body	Personal Audio Link Module																																																											
T	2011	ALL	Body	Base Radio																																																											
T	2011	ALL	Body	Uplevel Radio																																																											
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2011	ALL	Body	Theft Deterrent Module																																																											
T	2011	ALL	Body	Vehicle Comm. Interface Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																											
T	2012	Colorado (First Gen)	Body	Body Control Module																																																											
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																											
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																											
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																											
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																											
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																											
T	2012	Colorado (First Gen)	Body	Base Radio																																																											
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																										
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																										
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2012	Colorado (Second Gen)	Body	Body Control Module																																																										
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																										
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																										
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2012	S10	Powertrain	Transfer Case Control Module																																																										
T	2012	S10	Chassis	Electronic Brake Control Module																																																										
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2012	S10	Body	Body Control Module																																																										
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2012	S10	Body	Instrument Cluster																																																										
T	2012	S10	Body	Trailer Interface Control Module																																																										
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2013	Colorado	Powertrain	Transfer Case Control Module																																																										
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2013	Colorado	Body	Body Control Module																																																											
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	Colorado	Body	Instrument Cluster																																																											
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																											
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																											
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																											
T	2013	S10	Powertrain	Transfer Case Control Module																																																											
T	2013	S10	Chassis	Electronic Brake Control Module																																																											
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2013	S10	Body	Body Control Module																																																											
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	S10	Body	Instrument Cluster																																																											
T	2013	S10	Body	Trailer Interface Control Module																																																											
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																											
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																											
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																											
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																											
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2013	Trailblazer	Body	Body Control Module																																																											
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	Trailblazer	Body	Instrument Cluster																																																											
T	2013	Trailblazer	Body	Trailer Interface Control Module																																																											
T	2013	Trailblazer	Body	Parking Assist Control Module																																																											
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																											
T	2014	Colorado	Powertrain	Transfer Case Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																											
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2014	Colorado	Body	Body Control Module																																																												
T	2014	Colorado	Body	Body Control Module																																																												
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2014	Colorado	Body	Instrument Cluster																																																												
T	2014	Colorado	Body	Radio																																																												
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																												
T	2014	Colorado	Body	Parking Assist Control Module																																																												
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																												
T	2014	S10	Powertrain	Transfer Case Control Module																																																												
T	2014	S10	Chassis	Electronic Brake Control Module																																																												
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2014	S10	Body	Body Control Module																																																												
T	2014	S10	Body	Body Control Module																																																												
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2014	S10	Body	Instrument Cluster																																																												
T	2014	S10	Body	Trailer Interface Control Module																																																												
T	2014	S10	Body	Radio																																																												
T	2014	S10	Body	Parking Assist Control Module																																																												
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																												
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																												
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																												
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																												
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2014	Trailblazer	Body	Body Control Module																																																												
T	2014	Trailblazer	Body	Body Control Module																																																												
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2014	Trailblazer	Body	Instrument Cluster																																																												
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																												
T	2014	Trailblazer	Body	Parking Assist Control Module																																																												
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2015	Colorado	Powertrain	Chassis Control Module																																																												
T	2015	Colorado	Powertrain	Transfer Case Control Module																																																												
T	2015	Colorado	Chassis	Electronic Brake Control Module																																																												
T	2015	Colorado	Chassis	Power Steering Control Module																																																												
T	2015	Colorado	Body	Body Control Module																																																												
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2015	Colorado	Body	Passenger Presence Module																																																												
T	2015	Colorado	Body	Radio																																																											
T	2015	Colorado	Body	Amplifier																																																											
T	2015	Colorado	Body	Human Machine Interface Control Module																																																											
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																																											
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																											
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																											
T	2015	Colorado	Body	Frontview Camera Module																																																											
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																											
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																											
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2015	Colorado (MMM)	Body	Body Control Module																																																												
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2015	Colorado (MMM)	Body	Instrument Cluster																																																											
T	2015	Colorado (MMM)	Body	Radio																																																											
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																											
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																											
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																											
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																											
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2015	S10	Powertrain	Transfer Case Control Module																																																										
T	2015	S10	Chassis	Electronic Brake Control Module																																																										
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2015	S10	Body	Body Control Module																																																										
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	S10	Body	Instrument Cluster																																																										
T	2015	S10	Body	Trailer Interface Control Module																																																										
T	2015	S10	Body	Radio																																																										
T	2015	S10	Body	Telematics Communication Interface Control Module																																																										
T	2015	S10	Body	Parking Assist Control Module																																																										
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																										
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2015	Trailblazer	Body	Body Control Module																																																										
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2015	Trailblazer	Body	Instrument Cluster																																																										
T	2015	Trailblazer	Body	Trailer Interface Control Module																																																										
T	2015	Trailblazer	Body	Radio																																																										
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																										
T	2015	Trailblazer	Body	Parking Assist Control Module																																																										
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																										
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																										
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																										
T	2016	Colorado (1GC)	Body	Body Control Module																																																										
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																																										
T	2016	Colorado (1GC)	Body	Radio Controls																																																										
T	2016	Colorado (1GC)	Body	HVAC Controls																																																										
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																										
T	2016	Colorado (1GC)	Body	Radio																																																										
T	2016	Colorado (1GC)	Body	Amplifier																																																										
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																										
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																										
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																										
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																										
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																										
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																										
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2016	Colorado (MMM)	Body	Body Control Module																																																										
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																										
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																										
T	2016	Colorado (MMM)	Body	Radio																																																										
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																										
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																										
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																										
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																										
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
T	2016	S10	Powertrain	Transfer Case Control Module																																																										
T	2016	S10	Chassis	Electronic Brake Control Module																																																										
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2016	S10	Body	Body Control Module																																																										
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2016	S10	Body	Instrument Cluster																																																										
T	2016	S10	Body	Trailer Interface Control Module																																																										
T	2016	S10	Body	Radio																																																										
T	2016	S10	Body	Telematics Communication Interface Control Module																																																										
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																										
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																										
T	2016	S10	Body	Parking Assist Control Module																																																										
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																												
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																												
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2016	Trailblazer	Body	Body Control Module																																																												
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	Trailblazer	Body	Instrument Cluster																																																												
T	2016	Trailblazer	Body	Trailer Interface Control Module																																																												
T	2016	Trailblazer	Body	Radio																																																												
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																												
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																												
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	Trailblazer	Body	Parking Assist Control Module																																																												
V	2009	ALL	Powertrain	Engine Control Module																																																												
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2009	ALL	Powertrain	Rear Drive System																																																												
V	2009	ALL	Powertrain	Transmission Control Module																																																												
V	2009	ALL	Chassis	Electronic Brake Control Module																																																												
V	2009	ALL	Body	Body Control Module																																																												
V	2009	ALL	Body	Digital Radio Receiver																																																												
V	2009	ALL	Body	Driver Door Switch																																																												
V	2009	ALL	Body	Heated Seat Module																																																												
V	2009	ALL	Body	HVAC Control Module Auto																																																												
V	2009	ALL	Body	HVAC Control Module Manual																																																												
V	2009	ALL	Body	Instrument Panel Cluster																																																												
V	2009	ALL	Body	Lift Gate Module																																																												
V	2009	ALL	Body	Park Assist Module																																																												
V	2009	ALL	Body	Passenger Door Switch																																																												
V	2009	ALL	Body	Passenger Presence System																																																												
V	2009	ALL	Body	Radio																																																											
V	2009	ALL	Body	Rear HVAC/RSA																																																												
V	2009	ALL	Body	Rollover Sensor																																																												
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2009	ALL	Body	Theft Deterrent Module																																																												
V	2010	ALL	Powertrain	Engine Control Module																																																												
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2010	ALL	Powertrain	Rear Drive System																																																												
V	2010	ALL	Powertrain	Transmission Control Module																																																												
V	2010	ALL	Chassis	Electronic Brake Control Module																																																												
V	2010	ALL	Body	Body Control Module																																																												
V	2010	ALL	Body	Digital Radio Receiver																																																												
V	2010	ALL	Body	Driver Door Switch																																																												
V	2010	ALL	Body	Heated Seat Module																																																												
V	2010	ALL	Body	HVAC Control Module Auto																																																												
V	2010	ALL	Body	HVAC Control Module Manual																																																												
V	2010	ALL	Body	Instrument Panel Cluster																																																												
V	2010	ALL	Body	Lift Gate Module																																																												
V	2010	ALL	Body	Park Assist Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
V	2010	ALL	Body	Passenger Door Switch																																																										
V	2010	ALL	Body	Passenger Presence System																																																										
V	2010	ALL	Body	Radio																																																										
V	2010	ALL	Body	Rear HVAC/RSA																																																										
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2010	ALL	Body	Theft Deterrent Module																																																										
V	2011	ALL	Powertrain	Engine Control Module																																																										
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2011	ALL	Powertrain	Rear Drive System																																																										
V	2011	ALL	Powertrain	Transmission Control Module																																																										
V	2011	ALL	Chassis	Electronic Brake Control Module																																																										
V	2011	ALL	Body	Body Control Module																																																										
V	2011	ALL	Body	Digital Radio Receiver																																																										
V	2011	ALL	Body	Driver Door Switch																																																										
V	2011	ALL	Body	Heated Seat Module																																																										
V	2011	ALL	Body	HVAC Control Module Auto																																																										
V	2011	ALL	Body	HVAC Control Module Manual																																																										
V	2011	ALL	Body	Instrument Panel Cluster																																																										
V	2011	ALL	Body	Lift Gate Module																																																										
V	2011	ALL	Body	Park Assist Module																																																										
V	2011	ALL	Body	Passenger Door Switch																																																										
V	2011	ALL	Body	Passenger Presence System																																																										
V	2011	ALL	Body	Radio																																																										
V	2011	ALL	Body	Rear HVAC/RSA																																																										
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2011	ALL	Body	Theft Deterrent Module																																																										
V	2012	ALL	Powertrain	Engine Control Module																																																										
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2012	ALL	Powertrain	Rear Drive System																																																										
V	2012	ALL	Powertrain	Transmission Control Module																																																										
V	2012	ALL	Chassis	Electronic Brake Control Module																																																										
V	2012	ALL	Body	Body Control Module																																																										
V	2012	ALL	Body	Digital Radio Receiver																																																										
V	2012	ALL	Body	Driver Door Switch																																																										
V	2012	ALL	Body	Heated Seat Module																																																										
V	2012	ALL	Body	HVAC Control Module Auto																																																										
V	2012	ALL	Body	HVAC Control Module Manual																																																										
V	2012	ALL	Body	Instrument Panel Cluster																																																										
V	2012	ALL	Body	Lift Gate Module																																																										
V	2012	ALL	Body	Park Assist Module																																																										
V	2012	ALL	Body	Passenger Door Switch																																																										
V	2012	ALL	Body	Passenger Presence System																																																										
V	2012	ALL	Body	Radio																																																										
V	2012	ALL	Body	Rear HVAC/RSA																																																										
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2012	ALL	Body	Theft Deterrent Module																																																										
V	2013	ALL	Powertrain	Engine Control Module																																																										
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2013	ALL	Powertrain	Rear Drive System																																																										
V	2013	ALL	Powertrain	Transmission Control Module																																																										
V	2013	ALL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
V	2013	ALL	Body	Body Control Module																																																										
V	2013	ALL	Body	Digital Radio Receiver																																																										
V	2013	ALL	Body	Driver Door Switch																																																										
V	2013	ALL	Body	Heated Seat Module																																																										
V	2013	ALL	Body	HVAC Control Module Auto																																																										
V	2013	ALL	Body	HVAC Control Module Manual																																																										
V	2013	ALL	Body	Instrument Panel Cluster																																																										
V	2013	ALL	Body	Left Side Object Detection Module																																																										
V	2013	ALL	Body	Lift Gate Module																																																										
V	2013	ALL	Body	Park Assist Module																																																										
V	2013	ALL	Body	Passenger Door Switch																																																										
V	2013	ALL	Body	Passenger Presence System																																																										
V	2013	ALL	Body	Radio																																																										
V	2013	ALL	Body	Rear HVAC/RSA																																																										
V	2013	ALL	Body	Right Side Object Detection Module																																																										
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2013	ALL	Body	Theft Deterrent Module																																																										
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2014	Traverse	Powertrain	Chassis Control Module																																																										
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2014	Traverse	Chassis	Electronic Brake Control Module																																																										
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2014	Traverse	Body	Passenger Presence Module																																																										
V	2014	Traverse	Body	Instrument Cluster																																																										
V	2014	Traverse	Body	Radio																																																										
V	2014	Traverse	Body	Rear Audio Control Module																																																										
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2014	Traverse	Body	Personal Audio Link Control Module																																																										
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																											V																															
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																											V																															
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																										
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
V	2014	Traverse	Body	Liftgate Control Module																																																										
V	2014	Traverse	Body	Seat Memory Control Module																																																										
V	2014	Traverse	Body	Front Seat Heating Control Module																																																										
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2014	Traverse	Body	Parking Assist Control Module																																																										
V	2014	Traverse	Body	Frontview Camera Module																																																										
V	2014	Traverse	Body	Theft Deterrent Module																																																										
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2015	Traverse	Chassis	Electronic Brake Control Module																																																										
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																											
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2015	Traverse	Body	Passenger Presence Module																																																												
V	2015	Traverse	Body	Instrument Cluster																																																												
V	2015	Traverse	Body	Radio																																																												
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																												
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																											V																																	
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																											V																																	
V	2015	Traverse	Body	Liftgate Control Module																																																												
V	2015	Traverse	Body	Seat Memory Control Module																																																												
V	2015	Traverse	Body	Front Seat Heating Control Module																																																												
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																												
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																												
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																												
V	2015	Traverse	Body	Parking Assist Control Module																																																												
V	2015	Traverse	Body	Frontview Camera Module																																																												
V	2015	Traverse	Body	Theft Deterrent Module																																																												
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
V	2016	Traverse	Chassis	Electronic Brake Control Module																																																												
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																												
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																												
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2016	Traverse	Body	Passenger Presence Module																																																												
V	2016	Traverse	Body	Instrument Cluster																																																												
V	2016	Traverse	Body	Radio																																																												
V	2016	Traverse	Body	Rear Audio Control Module																																																												
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																												
V	2016	Traverse	Body	Personal Audio Link Control Module																																																												
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																												
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																											V																																	
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																											V																																	
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																												
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																												
V	2016	Traverse	Body	Liftgate Control Module																																																												
V	2016	Traverse	Body	Seat Memory Control Module																																																												
V	2016	Traverse	Body	Front Seat Heating Control Module																																																												
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																												
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																												
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																												
V	2016	Traverse	Body	Parking Assist Control Module																																																												
V	2016	Traverse	Body	Frontview Camera Module																																																												
V	2016	Traverse	Body	Theft Deterrent Module																																																												
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																												
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2011	Orlando	Chassis	Parking Brake Control Module																																																										
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2011	Orlando	Chassis	Power Steering Control Module																																																										
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2011	Orlando	Body	Body Control Module																																																										
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2011	Orlando	Body	Instrument Cluster																																																										
A	2011	Orlando	Body	Trailer Interface Control Module																																																										
A	2011	Orlando	Body	Radio																																																										
A	2011	Orlando	Body	Multimedia Player Interface Module																																																										
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
A	2011	Orlando	Body	Keyless Entry Control Module																																																										
A	2011	Orlando	Body	Parking Assist Control Module																																																										
A	2011	Orlando	Body	Steering Column Lock Control Module																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																										
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																										
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																										
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																										
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2012	Orlando	Chassis	Parking Brake Control Module																																																										
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2012	Orlando	Chassis	Power Steering Control Module																																																										
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2012	Orlando	Body	Body Control Module																																																										
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2012	Orlando	Body	Instrument Cluster																																																										
A	2012	Orlando	Body	Trailer Interface Control Module																																																										
A	2012	Orlando	Body	Radio																																																										
A	2012	Orlando	Body	Multimedia Player Interface Module																																																										
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																										
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																										
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																										
A	2012	Orlando	Body	Keyless Entry Control Module																																																										
A	2012	Orlando	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2012	Orlando	Body	Steering Column Lock Control Module																																																											
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																											
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																											
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																											
A	2013	Orlando	Chassis	Parking Brake Control Module																																																											
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2013	Orlando	Chassis	Power Steering Control Module																																																											
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2013	Orlando	Body	Body Control Module																																																											
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2013	Orlando	Body	Instrument Cluster																																																											
A	2013	Orlando	Body	Radio																																																											
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																											
A	2013	Orlando	Body	Multimedia Player Interface Module																																																											
A	2013	Orlando	Body	Mobile Telephone Control Module																																																											
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																										V																																
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																										V																																
A	2013	Orlando	Body	Front Seat Heating Control Module																																																											
A	2013	Orlando	Body	Keyless Entry Control Module																																																											
A	2013	Orlando	Body	Parking Assist Control Module																																																											
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																													
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																														
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																														
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																														
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																														
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																														
A	2014	Orlando	Chassis	Power Steering Control Module																																																														
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																														
A	2014	Orlando	Body	Body Control Module																																																														
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
A	2014	Orlando	Body	Instrument Cluster																																																														
A	2014	Orlando	Body	Radio																																																														
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																														
A	2014	Orlando	Body	Multimedia Player Interface Module																																																														
A	2014	Orlando	Body	Mobile Telephone Control Module																																																														
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																														
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																														
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																											V																																			
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																														
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																											V																																			
A	2014	Orlando	Body	Front Seat Heating Control Module																																																														
A	2014	Orlando	Body	Rear Seat Heating Control Module																																																														
A	2014	Orlando	Body	Keyless Entry Control Module																																																														
A	2014	Orlando	Body	Parking Assist Control Module																																																														
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																														
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																														
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																														
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																														
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																														
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																														
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																														
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																														
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																														
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																														
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																														
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																														
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																														
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																														
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																														
A	2015	Orlando	Chassis	Power Steering Control Module																																																														
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																														
A	2015	Orlando	Body	Body Control Module																																																														
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
A	2015	Orlando	Body	Instrument Cluster																																																														
A	2015	Orlando	Body	Radio																																																														
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																														
A	2015	Orlando	Body	Mobile Telephone Control Module																																																														

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																											
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																											V																																
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																											V																																
A	2015	Orlando	Body	Front Seat Heating Control Module																																																											
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																											
A	2015	Orlando	Body	Keyless Entry Control Module																																																											
A	2015	Orlando	Body	Parking Assist Control Module																				V																																							
A	2015	Orlando	Body	Frontview Camera Module																					V																																							
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																											
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																											
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																											
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																											
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																											
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																											
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																											
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																											
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																											
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2016	Orlando	Chassis	Power Steering Control Module																																																											
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2016	Orlando	Body	Body Control Module																																																											
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2016	Orlando	Body	Instrument Cluster																																																											
A	2016	Orlando	Body	Radio																																																											
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																											
A	2016	Orlando	Body	Multimedia Player Interface Module																																																											
A	2016	Orlando	Body	Mobile Telephone Control Module																																																											
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																											
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																											V																																
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																											V																																
A	2016	Orlando	Body	Front Seat Heating Control Module																																																											
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																											
A	2016	Orlando	Body	Keyless Entry Control Module																																																											
A	2016	Orlando	Body	Parking Assist Control Module																																																											
A	2016	Orlando	Body	Frontview Camera Module																																																											
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																												V				V																											
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																												V				V																											
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																												V				V																											
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																												V				V																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																												V				V																								
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																												V				V																								
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																							
C	2009	N200	Chassis	Electronic Brake Control Module																																																							
C	2009	N200	Body	Supplemental Inflatable Restraint																																																							
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																							
C	2009	N300	Chassis	Electronic Brake Control Module																																																							
C	2009	N300	Body	Supplemental Inflatable Restraint																																																							
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																							
C	2010	N200	Chassis	Electronic Brake Control Module																																																							
C	2010	N200	Body	Supplemental Inflatable Restraint																																																							
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																							
C	2010	N300	Chassis	Electronic Brake Control Module																																																							
C	2010	N300	Body	Supplemental Inflatable Restraint																																																							
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																							
C	2011	N200	Chassis	Electronic Brake Control Module																																																							
C	2011	N200	Body	Supplemental Inflatable Restraint																																																							
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																							
C	2011	N300	Chassis	Electronic Brake Control Module																																																							
C	2011	N300	Body	Supplemental Inflatable Restraint																																																							
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																							
C	2012	N200	Chassis	Electronic Brake Control Module																																																							
C	2012	N200	Body	Supplemental Inflatable Restraint																																																							
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																							
C	2012	N300	Chassis	Electronic Brake Control Module																																																							
C	2012	N300	Body	Supplemental Inflatable Restraint																																																							
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module	V	V					V																																																
C	2013	N300	Chassis	Electronic Brake Control Module																																																							
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module	V	V					V																																																
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																												V																												
C	2014	N300	Chassis	Electronic Brake Control Module																																																						
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module	V	V					V																																															
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																												V																											
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																												V																											
C	2015	Max	Chassis	Electronic Brake Control Module																																																						
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module	V	V					V																																															
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																												V																											
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																												V																											
C	2015	Move	Chassis	Electronic Brake Control Module																																																						
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module	V	V					V																																															
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																												V																											
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																												V																											
C	2015	N300	Chassis	Electronic Brake Control Module																																																						
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module	V	V					V																																																					
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																												V																																	
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																												V																																	
C	2016	Max	Chassis	Electronic Brake Control Module																																																												
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module	V	V					V																																																					
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																												V																																	
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																												V																																	
C	2016	Move	Chassis	Electronic Brake Control Module																																																												
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module	V	V					V																																																					
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																												V																																	
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																												V																																	
C	2016	N300	Chassis	Electronic Brake Control Module																																																												
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																												
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																											
M	2015	City Express	Chassis	Electronic Brake Control Module																																																											
M	2015	City Express	Chassis	Power Steering Control Module																																																											
M	2015	City Express	Body	Body Control Module																																																											
M	2015	City Express	Body	Underhood Fuse Block																																																											
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2015	City Express	Body	Instrument Cluster																																																											
M	2015	City Express	Body	Tire Pressure Indicator Module																																																											
M	2015	City Express	Body	Radio																																																											
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																											
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																											
M	2016	City Express	Chassis	Electronic Brake Control Module																																																											
M	2016	City Express	Chassis	Power Steering Control Module																																																											
M	2016	City Express	Body	Body Control Module																																																											
M	2016	City Express	Body	Underhood Fuse Block																																																											
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2016	City Express	Body	Instrument Cluster																																																											
M	2016	City Express	Body	Tire Pressure Indicator Module																																																											
M	2016	City Express	Body	Radio																																																											
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2011	Orlando	Chassis	Parking Brake Control Module																																																											
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2011	Orlando	Chassis	Power Steering Control Module																																																											
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
P	2011	Orlando	Body	Body Control Module																																																											
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2011	Orlando	Body	Instrument Cluster																																																											
P	2011	Orlando	Body	Trailer Interface Control Module																																																											
P	2011	Orlando	Body	Radio																																																											
P	2011	Orlando	Body	Multimedia Player Interface Module																																																											
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2011	Orlando	Body	Keyless Entry Control Module																																																											
P	2011	Orlando	Body	Parking Assist Control Module																																																											
P	2011	Orlando	Body	Steering Column Lock Control Module																																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																											
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2012	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2012	Orlando	Chassis	Parking Brake Control Module																																																											
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2012	Orlando	Chassis	Power Steering Control Module																																																											
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2012	Orlando	Body	Body Control Module																																																											
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2012	Orlando	Body	Instrument Cluster																																																											
P	2012	Orlando	Body	Trailer Interface Control Module																																																											
P	2012	Orlando	Body	Radio																																																											
P	2012	Orlando	Body	Multimedia Player Interface Module																																																											
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2012	Orlando	Body	Keyless Entry Control Module																																																											
P	2012	Orlando	Body	Parking Assist Control Module																																																											
P	2012	Orlando	Body	Steering Column Lock Control Module																																																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																										
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																										
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																										
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																										
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2013	Orlando	Chassis	Parking Brake Control Module																																																										
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2013	Orlando	Chassis	Power Steering Control Module																																																										
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2013	Orlando	Body	Body Control Module																																																										
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2013	Orlando	Body	Instrument Cluster																																																										
P	2013	Orlando	Body	Radio																																																										
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																										
P	2013	Orlando	Body	Multimedia Player Interface Module																																																										
P	2013	Orlando	Body	Mobile Telephone Control Module																																																										
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																											V																															
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																											V																															
P	2013	Orlando	Body	Front Seat Heating Control Module																																																										
P	2013	Orlando	Body	Keyless Entry Control Module																																																										
P	2013	Orlando	Body	Parking Assist Control Module																																																										
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
P	2014	Orlando	Chassis	Power Steering Control Module																																																											
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2014	Orlando	Body	Body Control Module																																																											
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2014	Orlando	Body	Instrument Cluster																																																											
P	2014	Orlando	Body	Radio																																																											
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																											
P	2014	Orlando	Body	Multimedia Player Interface Module																																																											
P	2014	Orlando	Body	Mobile Telephone Control Module																																																											
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																											V																																
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																											V																																
P	2014	Orlando	Body	Front Seat Heating Control Module																																																											
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																											
P	2014	Orlando	Body	Keyless Entry Control Module																																																											
P	2014	Orlando	Body	Parking Assist Control Module																																																											
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																											
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																											
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																											
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2015	Orlando	Chassis	Power Steering Control Module																																																											
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2015	Orlando	Body	Body Control Module																																																											
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2015	Orlando	Body	Instrument Cluster																																																											
P	2015	Orlando	Body	Radio																																																											
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																											
P	2015	Orlando	Body	Mobile Telephone Control Module																																																											
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																											
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																											V																																
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																											V																																
P	2015	Orlando	Body	Front Seat Heating Control Module																																																											
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																											
P	2015	Orlando	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
P	2015	Orlando	Body	Parking Assist Control Module																				V																																							
P	2015	Orlando	Body	Frontview Camera Module																					V																																							
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																											
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																											
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																											
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																											
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																											
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																											
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																											
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2016	Orlando	Chassis	Power Steering Control Module																																																											
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2016	Orlando	Body	Body Control Module																																																											
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2016	Orlando	Body	Instrument Cluster																																																											
P	2016	Orlando	Body	Radio																																																											
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																											
P	2016	Orlando	Body	Multimedia Player Interface Module																																																											
P	2016	Orlando	Body	Mobile Telephone Control Module																																																											
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																																											
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																											V																																
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																											V																																
P	2016	Orlando	Body	Front Seat Heating Control Module																																																											
P	2016	Orlando	Body	Rear Seat Heating Control Module																																																											
P	2016	Orlando	Body	Keyless Entry Control Module																																																											
P	2016	Orlando	Body	Parking Assist Control Module																																																											
P	2016	Orlando	Body	Frontview Camera Module																																																											
U	2004	ALL	Powertrain	Engine Control Module																																																											
U	2004	ALL	Powertrain	Transmission Control Module																																																											
U	2004	ALL	Body	Digital Radio Receiver																																																											
U	2004	ALL	Body	Driver Information Center																																																										
U	2004	ALL	Body	Instrument Panel Cluster																																																											
U	2004	ALL	Body	Radio																																																											
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
U	2004	ALL	Body	Vehicle Theft Deterrent																																																											
U	2005	ALL	Powertrain	Engine Control Module																																																											
U	2005	ALL	Powertrain	Transmission Control Module																																																											
U	2005	ALL	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
U	2005	ALL	Body	Body Control Module																																																										
U	2005	ALL	Body	Disc Player and Video																																																										
U	2005	ALL	Body	Digital Radio Receiver																																																										
U	2005	ALL	Body	HVAC Control Module																																																										
U	2005	ALL	Body	Instrument Panel Cluster																																																										
U	2005	ALL	Body	Left Power Sliding Door Module																																																										
U	2005	ALL	Body	Mobile Digital Media																																																										
U	2005	ALL	Body	Navigation Radio																																																										
U	2005	ALL	Body	Navigation Radio																																																										
U	2005	ALL	Body	Radio																																																										
U	2005	ALL	Body	Right Power Sliding Door Module																																																										
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																										
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																										
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																										
U	2006	ALL	Chassis	Electronic Brake Control Module																																																										
U	2006	ALL	Body	Body Control Module																																																										
U	2006	ALL	Body	Disc Player and Video																																																										
U	2006	ALL	Body	Digital Radio Receiver																																																										
U	2006	ALL	Body	HVAC Control Module																																																										
U	2006	ALL	Body	Instrument Panel Cluster																																																										
U	2006	ALL	Body	Left Power Sliding Door Module																																																										
U	2006	ALL	Body	Mobile Digital Media																																																										
U	2006	ALL	Body	Navigation Radio																																																										
U	2006	ALL	Body	Navigation Radio																																																										
U	2006	ALL	Body	Radio																																																										
U	2006	ALL	Body	Right Power Sliding Door Module																																																										
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																										
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
U	2007	ALL	Chassis	Electronic Brake Control Module																																																										
U	2007	ALL	Body	Body Control Module																																																										
U	2007	ALL	Body	Digital Radio Receiver																																																										
U	2007	ALL	Body	Disc Player and Video Display																																																										
U	2007	ALL	Body	HVAC Control Module																																																										
U	2007	ALL	Body	Left Power Sliding Door Module																																																										
U	2007	ALL	Body	Mobile Digital Media																																																										
U	2007	ALL	Body	Radio																																																										
U	2007	ALL	Body	Navigation Radio																																																										
U	2007	ALL	Body	Right Power Sliding Door Module																																																										
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																										
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
U	2008	ALL	Chassis	Electronic Brake Control Module																																																										
U	2008	ALL	Body	Body Control Module																																																										
U	2008	ALL	Body	Digital Radio Receiver																																																										
U	2008	ALL	Body	Disc Player and Video Display																																																										
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																											
U	2008	ALL	Body	Left Power Sliding Door Module																																																												
U	2008	ALL	Body	Radio																																																											
U	2008	ALL	Body	Navigation Radio																																																											
U	2008	ALL	Body	Remote Control Door Lock Receiver																																																												
U	2008	ALL	Body	Right Power Sliding Door Module																																																												
U	2009	ALL	Powertrain	Engine Control Module																																																												
U	2009	ALL	Powertrain	Transmission Control Module																																																												
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																												
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																												
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																												
U	2009	ALL	Body	Body Control Module																																																												
U	2009	ALL	Body	Digital Radio Receiver																																																												
U	2009	ALL	Body	Disc Player and Video Display																																																												
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																																												
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																												
U	2009	ALL	Body	Instrument Panel Cluster																																																												
U	2009	ALL	Body	Left Power Sliding Door Module																																																												
U	2009	ALL	Body	Radio																																																												
U	2009	ALL	Body	Remote Control Door Lock Receiver																																																												
U	2009	ALL	Body	Right Power Sliding Door Module																																																												
V	2004	ALL	Powertrain	Engine Data Display																																																												
V	2004	ALL	Powertrain	Transmission Data Display																																																												
V	2004	ALL	Body	Digital Radio Receiver																																																												
V	2004	ALL	Body	Driver Information Center																																																												
V	2004	ALL	Body	Instrument Panel Cluster																																																												
V	2004	ALL	Body	Radio																																																												
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2004	ALL	Body	Vehicle Theft Deterrent																																																												
V	2005	Venture	Powertrain	Engine Control Module																																																												
V	2005	Venture	Powertrain	Transmission Control Module																																																												
V	2005	Venture	Body	Digital Radio Receiver																																																												
V	2005	Venture	Body	Driver Information Center																																																												
V	2005	Venture	Body	Instrument Panel Cluster																																																												
V	2005	Venture	Body	Radio																																																												
V	2005	Venture	Body	Supplemental Inflatable Restraint																																																												
V	2005	Venture	Body	Vehicle Theft Deterrent																																																												
V	2005	Uplander	Powertrain	Engine Control Module																																																												
V	2005	Uplander	Powertrain	Transmission Control Module																																																												
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																												
V	2005	Uplander	Body	Body Control Module																																																												
V	2005	Uplander	Body	Disc Player and Video																																																												
V	2005	Uplander	Body	Digital Radio Receiver																																																												
V	2005	Uplander	Body	HVAC Control Module																																																												
V	2005	Uplander	Body	Instrument Panel Cluster																																																												
V	2005	Uplander	Body	Left Power Sliding Door Module																																																												
V	2005	Uplander	Body	Mobile Digital Media																																																												
V	2005	Uplander	Body	Navigation Radio																																																												
V	2005	Uplander	Body	Navigation Radio																																																												
V	2005	Uplander	Body	Radio																																																												
V	2005	Uplander	Body	Right Power Sliding Door Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
V	2005	Uplander	Body	Supplemental Inflatable Restraint																																																											
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																												
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																												
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																												
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																												
V	2006	ALL	Chassis	Electronic Brake Control Module																																																												
V	2006	ALL	Body	Body Control Module																																																												
V	2006	ALL	Body	Disc Player and Video																																																												
V	2006	ALL	Body	Digital Radio Receiver																																																												
V	2006	ALL	Body	HVAC Control Module																																																												
V	2006	ALL	Body	Instrument Panel Cluster																																																												
V	2006	ALL	Body	Left Power Sliding Door Module																																																												
V	2006	ALL	Body	Mobile Digital Media																																																												
V	2006	ALL	Body	Navigation Radio																																																												
V	2006	ALL	Body	Navigation Radio																																																												
V	2006	ALL	Body	Radio																																																												
V	2006	ALL	Body	Right Power Sliding Door Module																																																												
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																												
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																												
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																												
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																												
V	2007	ALL	Chassis	Electronic Brake Control Module																																																												
V	2007	ALL	Body	Body Control Module																																																												
V	2007	ALL	Body	Digital Radio Receiver																																																												
V	2007	ALL	Body	Disc Player and Video Display																																																												
V	2007	ALL	Body	HVAC Control Module																																																												
V	2007	ALL	Body	Left Power Sliding Door Module																																																												
V	2007	ALL	Body	Mobile Digital Media																																																												
V	2007	ALL	Body	Radio																																																												
V	2007	ALL	Body	Navigation Radio																																																												
V	2007	ALL	Body	Right Power Sliding Door Module																																																												
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																												
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																												
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																												
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																												
V	2008	ALL	Chassis	Electronic Brake Control Module																																																												
V	2008	ALL	Body	Body Control Module																																																												
V	2008	ALL	Body	Digital Radio Receiver																																																												
V	2008	ALL	Body	Disc Player and Video Display																																																												
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																																												
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																												
V	2008	ALL	Body	Left Power Sliding Door Module																																																												
V	2008	ALL	Body	Radio																																																												
V	2008	ALL	Body	Navigation Radio																																																												
V	2008	ALL	Body	Remote Control Door Lock Receiver																																																												
V	2008	ALL	Body	Right Power Sliding Door Module																																																												
V	2009	ALL	Powertrain	Engine Control Module																																																												
V	2009	ALL	Powertrain	Transmission Control Module																																																												
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																												
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																												
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
V	2009	ALL	Body	Body Control Module																																																												
V	2009	ALL	Body	Digital Radio Receiver																																																													
V	2009	ALL	Body	Disc Player and Video Display																																																													
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																																													
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																													
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																													
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																													
V	2009	ALL	Body	Left Power Sliding Door Module																																																													
V	2009	ALL	Body	Radio																																																													
V	2009	ALL	Body	Remote Control Door Lock Receiver																																																													
V	2009	ALL	Body	Right Power Sliding Door Module																																																													
X	2004	ALL	Powertrain	Engine Control Module																																																													
X	2004	ALL	Powertrain	Transmission Control Module																																																													
X	2004	ALL	Body	Digital Radio Receiver																																																													
X	2004	ALL	Body	Driver Information Center																																																													
X	2004	ALL	Body	Instrument Panel Cluster																																																													
X	2004	ALL	Body	Radio																																																													
X	2004	ALL	Body	Supplemental Inflatable Restraint																																																													
X	2004	ALL	Body	Vehicle Theft Deterrent																																																													
X	2005	ALL	Powertrain	Engine Control Module																																																														
X	2005	ALL	Powertrain	Transmission Control Module																																																													
X	2005	ALL	Chassis	Electronic Brake Control Module																																																													
X	2005	ALL	Body	Body Control Module																																																													
X	2005	ALL	Body	Disc Player and Video																																																													
X	2005	ALL	Body	Digital Radio Receiver																																																													
X	2005	ALL	Body	HVAC Control Module																																																													
X	2005	ALL	Body	Instrument Panel Cluster																																																													
X	2005	ALL	Body	Left Power Sliding Door Module																																																													
X	2005	ALL	Body	Mobile Digital Media																																																													
X	2005	ALL	Body	Navigation Radio																																																													
X	2005	ALL	Body	Navigation Radio																																																													
X	2005	ALL	Body	Radio																																																												
X	2005	ALL	Body	Right Power Sliding Door Module																																																													
X	2005	ALL	Body	Supplemental Inflatable Restraint																																																													
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																													
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																													
X	2006	ALL	Chassis	Electronic Brake Control Module																																																													
X	2006	ALL	Body	Body Control Module																																																													
X	2006	ALL	Body	Disc Player and Video																																																													
X	2006	ALL	Body	Digital Radio Receiver																																																													
X	2006	ALL	Body	HVAC Control Module																																																													
X	2006	ALL	Body	Instrument Panel Cluster																																																													
X	2006	ALL	Body	Left Power Sliding Door Module																																																													
X	2006	ALL	Body	Mobile Digital Media																																																													
X	2006	ALL	Body	Navigation Radio																																																													
X	2006	ALL	Body	Navigation Radio																																																													
X	2006	ALL	Body	Radio																																																												
X	2006	ALL	Body	Right Power Sliding Door Module																																																													

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2006	ALL	Powertrain	Transmission Control Module																																																										
A	2006	ALL	Chassis	Electronic Brake Control Module																																																										
A	2006	ALL	Chassis	Power Steering Control Module																																																										
A	2006	ALL	Body	Body Control Module																																																										
A	2006	ALL	Body	Digital Radio Receiver																																																										
A	2006	ALL	Body	Instrument Panel Cluster																																																										
A	2006	ALL	Body	Radio																																																										
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2006	ALL	Body	Theft Deterrent Module																																																										
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																										
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
A	2007	ALL	Chassis	Electronic Brake Control Module																																																										
A	2007	ALL	Chassis	Power Steering Control Module																																																										
A	2007	ALL	Body	Body Control Module																																																										
A	2007	ALL	Body	Digital Radio Receiver																																																										
A	2007	ALL	Body	Instrument Panel Cluster																																																										
A	2007	ALL	Body	Radio																																																										
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2007	ALL	Body	Theft Deterrent Module																																																										
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																										
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2008	HHR	Chassis	Power Steering Control Module																																																										
A	2008	HHR	Chassis	Power Steering Control Module																																																										
A	2008	HHR	Body	Body Control Module																																																										
A	2008	HHR	Body	Digital Radio Receiver																																																										
A	2008	HHR	Body	Instrument Panel Cluster																																																										
A	2008	HHR	Body	Radio																																																										
A	2008	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2008	HHR	Body	Theft Deterrent Module																																																										
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																										
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																										
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2008	HHR Panel	Body	Body Control Module																																																										
A	2008	HHR Panel	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2008	HHR Panel	Body	Radio																																																										
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2008	HHR Panel	Body	Theft Deterrent Module																																																										
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																																										
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2009	HHR	Chassis	Power Steering Control Module																																																										
A	2009	HHR	Chassis	Power Steering Control Module																																																										
A	2009	HHR	Body	Body Control Module																																																										
A	2009	HHR	Body	Digital Radio Receiver																																																										
A	2009	HHR	Body	Instrument Panel Cluster																																																										
A	2009	HHR	Body	Radio																																																										
A	2009	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2009	HHR	Body	Theft Deterrent Module																																																										
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2009	HHR Panel	Body	Body Control Module																																																										
A	2009	HHR Panel	Body	Digital Radio Receiver																																																										
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2009	HHR Panel	Body	Radio																																																										
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2009	HHR Panel	Body	Theft Deterrent Module																																																										
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																										
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2010	HHR	Chassis	Power Steering Control Module																																																										
A	2010	HHR	Chassis	Power Steering Control Module																																																										
A	2010	HHR	Body	Body Control Module																																																										
A	2010	HHR	Body	Digital Radio Receiver																																																										
A	2010	HHR	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2010	HHR	Body	Radio																																																										
A	2010	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2010	HHR	Body	Theft Deterrent Module																																																										
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																										
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																										
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2010	HHR Panel	Body	Body Control Module																																																										
A	2010	HHR Panel	Body	Digital Radio Receiver																																																										
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2010	HHR Panel	Body	Radio																																																										
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2010	HHR Panel	Body	Theft Deterrent Module																																																										
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																										
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																										
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																										
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																										
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2011	HHR	Chassis	Power Steering Control Module																																																										
A	2011	HHR	Body	Body Control Module																																																										
A	2011	HHR	Body	Digital Radio Receiver																																																										
A	2011	HHR	Body	Instrument Panel Cluster																																																										
A	2011	HHR	Body	Radio																																																										
A	2011	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2011	HHR	Body	Theft Deterrent Module																																																										
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																										
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																										
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																										
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																										
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2011	HHR Panel	Body	Body Control Module																																																										
A	2011	HHR Panel	Body	Digital Radio Receiver																																																										
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2011	HHR Panel	Body	Radio																																																										
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2011	HHR Panel	Body	Theft Deterrent Module																																																										
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																									
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																									
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V			V	V																														
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V			V	V																														
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																									
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																									
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer												V													V	V																															
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer												V													V	V																															
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer												V													V																																
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																									
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer												V													V	V																															
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																									
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																									
A	2013	Trax	Chassis	Electronic Brake Control Module																																																									
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2013	Trax	Chassis	Power Steering Control Module																																																									
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2013	Trax	Body	Body Control Module																																																								
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2013	Trax	Body	Passenger Presence Module																																																									
A	2013	Trax	Body	Instrument Cluster																																																									
A	2013	Trax	Body	Radio																																																									
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																									
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																									
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																									
A	2013	Trax	Body	Front Seat Heating Control Module																																																									
A	2013	Trax	Body	Parking Assist Control Module																																																									
A	2013	Trax	Body	Frontview Camera Module																																																									
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																									
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V			V	V																														

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V			V	V																												
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																								
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer												V													V	V																															
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																								
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer												V													V	V																															
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																								
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																								
A	2014	Trax	Chassis	Electronic Brake Control Module																																																								
A	2014	Trax	Chassis	Power Steering Control Module																																																								
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2014	Trax	Body	Body Control Module																																																								
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2014	Trax	Body	Passenger Presence Module																																																								
A	2014	Trax	Body	Instrument Cluster																																																								
A	2014	Trax	Body	Radio																																																								
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
A	2014	Trax	Body	Front Seat Heating Control Module																																																								
A	2014	Trax	Body	Parking Assist Control Module																																																								
A	2014	Trax	Body	Frontview Camera Module																																																								
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																								
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																								
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V			V	V																													
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V			V	V																													
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																								
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission												V													V	V																															
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission												V													V	V																															
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																								
A	2015	Trax	Powertrain	Chassis Control Module																																																								
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																								
A	2015	Trax	Chassis	Electronic Brake Control Module																																																								
A	2015	Trax	Chassis	Power Steering Control Module																																																								
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2015	Trax	Body	Body Control Module																																																								
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2015	Trax	Body	Passenger Presence Module																																																								
A	2015	Trax	Body	Instrument Cluster																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2015	Trax	Body	Radio																																																									
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																									
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																									
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																									
A	2015	Trax	Body	Seat Memory Control Module																																																									
A	2015	Trax	Body	Front Seat Heating Control Module																																																									
A	2015	Trax	Body	Right Side Object Detection Control Module																																																									
A	2015	Trax	Body	Left Side Object Detection Control Module																																																									
A	2015	Trax	Body	Parking Assist Control Module																																																									
A	2015	Trax	Body	Frontview Camera Module																																																									
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																									
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																									
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																									
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																									
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																									
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																									
A	2016	Trax	Powertrain	Chassis Control Module																																																									
A	2016	Trax	Chassis	Electronic Brake Control Module																																																									
A	2016	Trax	Chassis	Power Steering Control Module																																																									
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2016	Trax	Body	Body Control Module																																																									
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2016	Trax	Body	Passenger Presence Module																																																									
A	2016	Trax	Body	Instrument Cluster																																																									
A	2016	Trax	Body	Trailer Interface Control Module																																																									
A	2016	Trax	Body	Radio																																																									
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																									
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																									
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																									
A	2016	Trax	Body	Seat Memory Control Module																																																									
A	2016	Trax	Body	Front Seat Heating Control Module																																																									
A	2016	Trax	Body	Right Side Object Detection Control Module																																																									
A	2016	Trax	Body	Left Side Object Detection Control Module																																																									
A	2016	Trax	Body	Parking Assist Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2016	Trax	Body	Frontview Camera Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																									
C	2004	ALL	Body	CD Changer																																																									
C	2004	ALL	Body	Chime																																																									
C	2004	ALL	Body	Driver Door Module																																																									
C	2004	ALL	Body	Driver Seat Module																																																									
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2004	ALL	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2004	ALL	Body	OnStar																																																									
C	2004	ALL	Body	Passenger Door Module																																																									
C	2004	ALL	Body	Passenger Presence System																																																									
C	2004	ALL	Body	Radio Base																																																									
C	2004	ALL	Body	Radio Uplevel																																																									
C	2004	ALL	Body	Radio Navigation																																																									
C	2004	ALL	Body	Rear Aux. Climate Module																																																										
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																										
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2004	ALL	Body	Vehicle Theft Deterrent																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								V			
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2005	ALL	Chassis	ESC																																																									
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2005	ALL	Chassis	VSES																																																									
C	2005	ALL	Body	Amplifier (Bose)																																																									
C	2005	ALL	Body	Body Control Module																																																									
C	2005	ALL	Body	CD Changer																																																									
C	2005	ALL	Body	Chime																																																									
C	2005	ALL	Body	Disc Player and Video Display																																																									
C	2005	ALL	Body	Driver Door Module																																																									
C	2005	ALL	Body	Driver Seat Module																																																									
C	2005	ALL	Body	Generator Battery Control Module																																																									
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																									
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																									
C	2005	ALL	Body	Instrument Panel Cluster																																																									
C	2005	ALL	Body	Passenger Door Module																																																									
C	2005	ALL	Body	Passenger Presence System																																																									
C	2005	ALL	Body	Base Radio																																																									
C	2005	ALL	Body	Uplevel Radio																																																									
C	2005	ALL	Body	Navigation Radio																																																									
C	2005	ALL	Body	Rear Aux. Climate Module																																																									
C	2005	ALL	Body	Rear HVAC																																																									
C	2005	ALL	Body	Rear Seat Audio																																																									
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																									
C	2005	ALL	Body	Vehicle Theft Deterrent																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																									
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																								
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								V			
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																									
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																										
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2007	Avalanche	Body	Amplifier (Bose)																																																											
C	2007	Avalanche	Body	Assist Step Controller																																																											
C	2007	Avalanche	Body	Body Control Module																																																											
C	2007	Avalanche	Body	Body Control Module (aux.)																																																											
C	2007	Avalanche	Body	Digital Radio Receiver																																																											
C	2007	Avalanche	Body	Driver Door Switch																																																											
C	2007	Avalanche	Body	HVAC Control Module Auto																																																											
C	2007	Avalanche	Body	HVAC Control Module Manual																																																											
C	2007	Avalanche	Body	Instrument Panel Cluster																																																											
C	2007	Avalanche	Body	Memory Seat Module																																																											
C	2007	Avalanche	Body	Park Assist Module																																																											
C	2007	Avalanche	Body	Passenger Door Switch																																																											
C	2007	Avalanche	Body	Passenger Presence System																																																											
C	2007	Avalanche	Body	Radio																																																											
C	2007	Avalanche	Body	Rear Heated Seat Module																																																											
C	2007	Avalanche	Body	Rear HVAC/RSA																																																											
C	2007	Avalanche	Body	Rollover Sensor																																																											
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																											
C	2007	Avalanche	Body	Theft Deterrent Module																																																											
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2007	Suburban	Chassis	Electronic Suspension Control																																																											
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																											
C	2007	Suburban	Body	Amplifier (Bose)																																																											
C	2007	Suburban	Body	Assist Step Controller																																																											
C	2007	Suburban	Body	Body Control Module																																																											
C	2007	Suburban	Body	Body Control Module (aux.)																																																											
C	2007	Suburban	Body	Digital Radio Receiver																																																											
C	2007	Suburban	Body	Driver Door Switch																																																											
C	2007	Suburban	Body	HVAC Control Module Auto																																																											
C	2007	Suburban	Body	HVAC Control Module Manual																																																											
C	2007	Suburban	Body	Instrument Panel Cluster																																																											
C	2007	Suburban	Body	Lift Gate Module																																																											
C	2007	Suburban	Body	Memory Seat Module																																																											
C	2007	Suburban	Body	Park Assist Module																																																											
C	2007	Suburban	Body	Passenger Door Switch																																																											
C	2007	Suburban	Body	Passenger Presence System																																																											
C	2007	Suburban	Body	Radio																																																											
C	2007	Suburban	Body	Rear Heated Seat Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2007	Suburban	Body	Rear HVAC/RSA																																																										
C	2007	Suburban	Body	Rollover Sensor																																																										
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2007	Suburban	Body	Theft Deterrent Module																																																										
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V											V			V						
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																														
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Silverado	Chassis	Electronic Suspension Control																																																										
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																										
C	2007	Silverado	Body	Amplifier (Bose)																																																										
C	2007	Silverado	Body	Body Control Module																																																									
C	2007	Silverado	Body	Body Control Module (aux.)																																																										
C	2007	Silverado	Body	Digital Radio Receiver																																																										
C	2007	Silverado	Body	Driver Door Switch																																																										
C	2007	Silverado	Body	HVAC Control Module Auto																																																										
C	2007	Silverado	Body	HVAC Control Module Manual																																																										
C	2007	Silverado	Body	Instrument Panel Cluster																																																										
C	2007	Silverado	Body	Memory Seat Module																																																										
C	2007	Silverado	Body	Park Assist Module																																																										
C	2007	Silverado	Body	Passenger Door Switch																																																										
C	2007	Silverado	Body	Passenger Presence System																																																										
C	2007	Silverado	Body	Radio																																																										
C	2007	Silverado	Body	Rear Heated Seat Module																																																										
C	2007	Silverado	Body	Rear HVAC/RSA																																																										
C	2007	Silverado	Body	Rollover Sensor																																																										
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2007	Silverado	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2007	Tahoe	Body	Amplifier (Bose)																																																										
C	2007	Tahoe	Body	Assist Step Controller																																																										
C	2007	Tahoe	Body	Body Control Module																																																										
C	2007	Tahoe	Body	Body Control Module (aux.)																																																										
C	2007	Tahoe	Body	Digital Radio Receiver																																																										
C	2007	Tahoe	Body	Driver Door Switch																																																										
C	2007	Tahoe	Body	HVAC Control Module Auto																																																										
C	2007	Tahoe	Body	HVAC Control Module Manual																																																										
C	2007	Tahoe	Body	Instrument Panel Cluster																																																										
C	2007	Tahoe	Body	Lift Gate Module																																																										
C	2007	Tahoe	Body	Memory Seat Module																																																										
C	2007	Tahoe	Body	Park Assist Module																																																										
C	2007	Tahoe	Body	Passenger Door Switch																																																										
C	2007	Tahoe	Body	Passenger Presence System																																																										
C	2007	Tahoe	Body	Radio																																																										
C	2007	Tahoe	Body	Rear Heated Seat Module																																																										
C	2007	Tahoe	Body	Rear HVAC/RSA																																																										
C	2007	Tahoe	Body	Rollover Sensor																																																										
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2007	Tahoe	Body	Theft Deterrent Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2008	Avalanche	Body	Amplifier (Bose)																																																										
C	2008	Avalanche	Body	Assist Step Controller																																																										
C	2008	Avalanche	Body	Body Control Module																																																										
C	2008	Avalanche	Body	Body Control Module (aux.)																																																										
C	2008	Avalanche	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2008	Avalanche	Body	Driver Door Switch																																																										
C	2008	Avalanche	Body	HVAC Control Module Auto																																																											
C	2008	Avalanche	Body	HVAC Control Module Manual																																																											
C	2008	Avalanche	Body	Instrument Panel Cluster																																																											
C	2008	Avalanche	Body	Memory Seat Module																																																											
C	2008	Avalanche	Body	Park Assist Module																																																											
C	2008	Avalanche	Body	Passenger Door Switch																																																											
C	2008	Avalanche	Body	Passenger Presence System																																																											
C	2008	Avalanche	Body	Radio																																																											
C	2008	Avalanche	Body	Rear Heated Seat Module																																																											
C	2008	Avalanche	Body	Rear HVAC/RSA																																																											
C	2008	Avalanche	Body	Rollover Sensor																																																											
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																											
C	2008	Avalanche	Body	Theft Deterrent Module																																																											
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2008	Suburban	Chassis	Electronic Suspension Control																																																											
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																											
C	2008	Suburban	Body	Amplifier (Bose)																																																											
C	2008	Suburban	Body	Assist Step Controller																																																											
C	2008	Suburban	Body	Body Control Module																																																										
C	2008	Suburban	Body	Body Control Module (aux.)																																																											
C	2008	Suburban	Body	Digital Radio Receiver																																																											
C	2008	Suburban	Body	Driver Door Switch																																																											
C	2008	Suburban	Body	HVAC Control Module Auto																																																											
C	2008	Suburban	Body	HVAC Control Module Manual																																																											
C	2008	Suburban	Body	Instrument Panel Cluster																																																											
C	2008	Suburban	Body	Lift Gate Module																																																											
C	2008	Suburban	Body	Memory Seat Module																																																											
C	2008	Suburban	Body	Park Assist Module																																																											
C	2008	Suburban	Body	Passenger Door Switch																																																											
C	2008	Suburban	Body	Passenger Presence System																																																											
C	2008	Suburban	Body	Radio																																																											
C	2008	Suburban	Body	Rear Heated Seat Module																																																											
C	2008	Suburban	Body	Rear HVAC/RSA																																																											
C	2008	Suburban	Body	Rollover Sensor																																																											
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2008	Suburban	Body	Theft Deterrent Module																																																								
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																										V									V												V				V				
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																												V																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2008	Silverado	Chassis	Electronic Suspension Control																																																								
C	2008	Silverado	Chassis	Trailer Brake Control Module																																																								
C	2008	Silverado	Body	Amplifier (Bose)																																																								
C	2008	Silverado	Body	Body Control Module																																																								
C	2008	Silverado	Body	Body Control Module (aux.)																																																								
C	2008	Silverado	Body	Digital Radio Receiver																																																								
C	2008	Silverado	Body	Driver Door Switch																																																								
C	2008	Silverado	Body	HVAC Control Module Auto																																																								
C	2008	Silverado	Body	HVAC Control Module Manual																																																								
C	2008	Silverado	Body	Instrument Panel Cluster																																																								
C	2008	Silverado	Body	Memory Seat Module																																																								
C	2008	Silverado	Body	Park Assist Module																																																								
C	2008	Silverado	Body	Passenger Door Switch																																																								
C	2008	Silverado	Body	Passenger Presence System																																																								
C	2008	Silverado	Body	Radio																																																								
C	2008	Silverado	Body	Rear Heated Seat Module																																																								
C	2008	Silverado	Body	Rear HVAC/RSA																																																								
C	2008	Silverado	Body	Rollover Sensor																																																								
C	2008	Silverado	Body	Supplemental Inflatable Restraint																																																								
C	2008	Silverado	Body	Theft Deterrent Module																																																								
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																																								
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2008	Tahoe	Body	Amplifier (Bose)																																																										
C	2008	Tahoe	Body	Assist Step Controller																																																										
C	2008	Tahoe	Body	Body Control Module																																																										
C	2008	Tahoe	Body	Body Control Module (aux.)																																																										
C	2008	Tahoe	Body	Digital Radio Receiver																																																										
C	2008	Tahoe	Body	Driver Door Switch																																																										
C	2008	Tahoe	Body	HVAC Control Module Auto																																																										
C	2008	Tahoe	Body	HVAC Control Module Manual																																																										
C	2008	Tahoe	Body	Instrument Panel Cluster																																																										
C	2008	Tahoe	Body	Memory Seat Module																																																										
C	2008	Tahoe	Body	Park Assist Module																																																										
C	2008	Tahoe	Body	Passenger Presence System																																																										
C	2008	Tahoe	Body	Radio																																																										
C	2008	Tahoe	Body	Rear Heated Seat Module																																																										
C	2008	Tahoe	Body	Rear HVAC/RSA																																																										
C	2008	Tahoe	Body	Rollover Sensor																																																										
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2008	Tahoe	Body	Theft Deterrent Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2008	Tahoe Hybrid	Body	Body Control Module																																																										
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2008	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2008	Tahoe Hybrid	Body	Memory Seat Module																																																										
C	2008	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2008	Tahoe Hybrid	Body	Radio																																																										
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																																										
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2009	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2009	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2009	Avalanche	Body	Amplifier (Bose)																																																										
C	2009	Avalanche	Body	Assist Step Controller																																																										
C	2009	Avalanche	Body	Body Control Module																																																										
C	2009	Avalanche	Body	Body Control Module (aux.)																																																										
C	2009	Avalanche	Body	Digital Radio Receiver																																																										
C	2009	Avalanche	Body	Driver Door Switch																																																										
C	2009	Avalanche	Body	HVAC Control Module Auto																																																										
C	2009	Avalanche	Body	HVAC Control Module Manual																																																										
C	2009	Avalanche	Body	Instrument Panel Cluster																																																										
C	2009	Avalanche	Body	Memory Seat Module																																																										
C	2009	Avalanche	Body	Park Assist Module																																																										
C	2009	Avalanche	Body	Passenger Door Switch																																																										
C	2009	Avalanche	Body	Passenger Presence System																																																										
C	2009	Avalanche	Body	Radio																																																										
C	2009	Avalanche	Body	Rear Heated Seat Module																																																										
C	2009	Avalanche	Body	Rear HVAC/RSA																																																										
C	2009	Avalanche	Body	Rollover Sensor																																																										
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2009	Avalanche	Body	Theft Deterrent Module																																																										
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																											
C	2009	Cheyenne	Body	Amplifier (Bose)																																																											
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																											
C	2009	Cheyenne	Body	Digital Radio Receiver																																																											
C	2009	Cheyenne	Body	Driver Door Switch																																																											
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																											
C	2009	Cheyenne	Body	Park Assist Module																																																											
C	2009	Cheyenne	Body	Passenger Door Switch																																																											
C	2009	Cheyenne	Body	Passenger Presence System																																																											
C	2009	Cheyenne	Body	Rear Heated Seat Module																																																											
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																											
C	2009	Cheyenne	Body	Rollover Sensor																																																											
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
C	2009	Cheyenne	Body	Theft Deterrent Module																																																											
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																											
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2009	Suburban	Chassis	Electronic Suspension Control																																																											
C	2009	Suburban	Chassis	Trailer Brake Control Module																																																											
C	2009	Suburban	Body	Amplifier (Bose)																																																											
C	2009	Suburban	Body	Assist Step Controller																																																											
C	2009	Suburban	Body	Body Control Module																																																											
C	2009	Suburban	Body	Body Control Module (aux.)																																																											
C	2009	Suburban	Body	Digital Radio Receiver																																																											
C	2009	Suburban	Body	Driver Door Switch																																																											
C	2009	Suburban	Body	HVAC Control Module Auto																																																											
C	2009	Suburban	Body	HVAC Control Module Manual																																																											
C	2009	Suburban	Body	Instrument Panel Cluster																																																											
C	2009	Suburban	Body	Left Side Object Detection Module																																																											
C	2009	Suburban	Body	Lift Gate Module																																																											
C	2009	Suburban	Body	Memory Seat Module																																																											
C	2009	Suburban	Body	Park Assist Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2009	Suburban	Body	Passenger Door Switch																																																										
C	2009	Suburban	Body	Passenger Presence System																																																										
C	2009	Suburban	Body	Radio																																																										
C	2009	Suburban	Body	Rear Heated Seat Module																																																										
C	2009	Suburban	Body	Rear HVAC/RSA																																																										
C	2009	Suburban	Body	Right Side Object Detection Module																																																										
C	2009	Suburban	Body	Rollover Sensor																																																										
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2009	Suburban	Body	Theft Deterrent Module																																																										
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V										V				V						
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																														
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2009	Silverado	Chassis	Electronic Suspension Control																																																										
C	2009	Silverado	Chassis	Trailer Brake Control Module																																																										
C	2009	Silverado	Body	Amplifier (Bose)																																																										
C	2009	Silverado	Body	Body Control Module																																																										
C	2009	Silverado	Body	Body Control Module (aux.)																																																										
C	2009	Silverado	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2009	Silverado	Body	Driver Door Switch																																																										
C	2009	Silverado	Body	HVAC Control Module Auto																																																											
C	2009	Silverado	Body	HVAC Control Module Manual																																																											
C	2009	Silverado	Body	Instrument Panel Cluster																																																											
C	2009	Silverado	Body	Memory Seat Module																																																											
C	2009	Silverado	Body	Park Assist Module																																																											
C	2009	Silverado	Body	Passenger Door Switch																																																											
C	2009	Silverado	Body	Passenger Presence System																																																											
C	2009	Silverado	Body	Radio																																																											
C	2009	Silverado	Body	Rear Heated Seat Module																																																											
C	2009	Silverado	Body	Rear HVAC/RSA																																																											
C	2009	Silverado	Body	Rollover Sensor																																																											
C	2009	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2009	Silverado	Body	Theft Deterrent Module																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																											
C	2009	Silverado Hybrid	Body	Body Control Module																																																											
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																											
C	2009	Silverado Hybrid	Body	Driver Door Switch																																																											
C	2009	Silverado Hybrid	Body	HVAC Control Module																																																											
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
C	2009	Silverado Hybrid	Body	Memory Seat Module																																																											
C	2009	Silverado Hybrid	Body	Park Assist Module																																																											
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2009	Silverado Hybrid	Body	Passenger Presence System																																																											
C	2009	Silverado Hybrid	Body	Radio																																																											
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
C	2009	Silverado Hybrid	Body	Rollover Sensor																																																											
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2009	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																																											
C	2009	Tahoe	Body	Amplifier (Bose)																																																											
C	2009	Tahoe	Body	Assist Step Controller																																																											
C	2009	Tahoe	Body	Body Control Module																																																											
C	2009	Tahoe	Body	Body Control Module (aux.)																																																											
C	2009	Tahoe	Body	Digital Radio Receiver																																																											
C	2009	Tahoe	Body	Driver Door Switch																																																											
C	2009	Tahoe	Body	HVAC Control Module Auto																																																											
C	2009	Tahoe	Body	HVAC Control Module Manual																																																											
C	2009	Tahoe	Body	Instrument Panel Cluster																																																											
C	2009	Tahoe	Body	Left Side Object Detection Module																																																											
C	2009	Tahoe	Body	Lift Gate Module																																																											
C	2009	Tahoe	Body	Memory Seat Module																																																											
C	2009	Tahoe	Body	Park Assist Module																																																											
C	2009	Tahoe	Body	Passenger Door Switch																																																											
C	2009	Tahoe	Body	Passenger Presence System																																																											
C	2009	Tahoe	Body	Radio																																																										
C	2009	Tahoe	Body	Rear Heated Seat Module																																																											
C	2009	Tahoe	Body	Rear HVAC/RSA																																																											
C	2009	Tahoe	Body	Right Side Object Detection Module																																																											
C	2009	Tahoe	Body	Rollover Sensor																																																											
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																											
C	2009	Tahoe	Body	Theft Deterrent Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																											
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2009	Tahoe Hybrid	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																																											
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																																											
C	2009	Tahoe Hybrid	Body	HVAC Control Module																																																											
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
C	2009	Tahoe Hybrid	Body	Park Assist Module																																																											
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																											
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																																											
C	2009	Tahoe Hybrid	Body	Radio																																																											
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																											
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	Avalanche	Chassis	Electronic Brake Control Module																																																											
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																											
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Avalanche	Body	Amplifier (Bose)																																																											
C	2010	Avalanche	Body	Assist Step Controller																																																											
C	2010	Avalanche	Body	Body Control Module																																																											
C	2010	Avalanche	Body	Body Control Module (aux.)																																																											
C	2010	Avalanche	Body	Digital Radio Receiver																																																											
C	2010	Avalanche	Body	Driver Door Switch																																																											
C	2010	Avalanche	Body	HVAC Control Module Auto																																																											
C	2010	Avalanche	Body	HVAC Control Module Manual																																																											
C	2010	Avalanche	Body	Instrument Panel Cluster																																																											
C	2010	Avalanche	Body	Memory Seat Module																																																											
C	2010	Avalanche	Body	Park Assist Module																																																											
C	2010	Avalanche	Body	Passenger Door Switch																																																											
C	2010	Avalanche	Body	Passenger Presence System																																																											
C	2010	Avalanche	Body	Radio																																																											
C	2010	Avalanche	Body	Rear Heated Seat Module																																																											
C	2010	Avalanche	Body	Rear HVAC/RSA																																																											
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																											
C	2010	Avalanche	Body	Theft Deterrent Module																																																											
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Cheyenne	Body	Amplifier (Bose)																																																										
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2010	Cheyenne	Body	Digital Radio Receiver																																																										
C	2010	Cheyenne	Body	Driver Door Switch																																																										
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2010	Cheyenne	Body	Park Assist Module																																																										
C	2010	Cheyenne	Body	Passenger Door Switch																																																										
C	2010	Cheyenne	Body	Passenger Presence System																																																										
C	2010	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2010	Cheyenne	Body	Theft Deterrent Module																																																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2010	Suburban	Chassis	Electronic Suspension Control																																																										
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Suburban	Body	Amplifier (Bose)																																																										
C	2010	Suburban	Body	Assist Step Controller																																																										
C	2010	Suburban	Body	Body Control Module																																																										
C	2010	Suburban	Body	Body Control Module (aux.)																																																										
C	2010	Suburban	Body	Digital Radio Receiver																																																										
C	2010	Suburban	Body	Driver Door Switch																																																										
C	2010	Suburban	Body	HVAC Control Module Auto																																																										
C	2010	Suburban	Body	HVAC Control Module Manual																																																										
C	2010	Suburban	Body	Instrument Panel Cluster																																																										
C	2010	Suburban	Body	Left Side Object Detection Module																																																										
C	2010	Suburban	Body	Lift Gate Module																																																										
C	2010	Suburban	Body	Memory Seat Module																																																										
C	2010	Suburban	Body	Park Assist Module																																																										
C	2010	Suburban	Body	Passenger Door Switch																																																										
C	2010	Suburban	Body	Passenger Presence System																																																										
C	2010	Suburban	Body	Radio																																																										
C	2010	Suburban	Body	Rear Heated Seat Module																																																										
C	2010	Suburban	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2010	Suburban	Body	Right Side Object Detection Module																																																										
C	2010	Suburban	Body	Supplemental Inflatable Restraint																																																											
C	2010	Suburban	Body	Theft Deterrent Module																																																											
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																											
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																											
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V											V			V					
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																															
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2010	Silverado	Chassis	Electronic Suspension Control																																																											
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2010	Silverado	Body	Amplifier (Bose)																																																											
C	2010	Silverado	Body	Body Control Module																																																											
C	2010	Silverado	Body	Body Control Module (aux.)																																																											
C	2010	Silverado	Body	Digital Radio Receiver																																																											
C	2010	Silverado	Body	Driver Door Switch																																																											
C	2010	Silverado	Body	HVAC Control Module Auto																																																											
C	2010	Silverado	Body	HVAC Control Module Manual																																																											
C	2010	Silverado	Body	Instrument Panel Cluster																																																											
C	2010	Silverado	Body	Memory Seat Module																																																											
C	2010	Silverado	Body	Park Assist Module																																																											
C	2010	Silverado	Body	Passenger Door Switch																																																											
C	2010	Silverado	Body	Passenger Presence System																																																											
C	2010	Silverado	Body	Radio																																																											
C	2010	Silverado	Body	Rear Heated Seat Module																																																											
C	2010	Silverado	Body	Rear HVAC/RSA																																																											
C	2010	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2010	Silverado	Body	Theft Deterrent Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2010	Silverado Hybrid	Body	Body Control Module																																																										
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2010	Silverado Hybrid	Body	HVAC Control Module																																																										
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2010	Silverado Hybrid	Body	Park Assist Module																																																										
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2010	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2010	Silverado Hybrid	Body	Radio																																																										
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																										
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Tahoe	Body	Amplifier (Bose)																																																										
C	2010	Tahoe	Body	Assist Step Controller																																																										
C	2010	Tahoe	Body	Body Control Module																																																										
C	2010	Tahoe	Body	Body Control Module (aux.)																																																										
C	2010	Tahoe	Body	Digital Radio Receiver																																																										
C	2010	Tahoe	Body	Driver Door Switch																																																										
C	2010	Tahoe	Body	HVAC Control Module Auto																																																										
C	2010	Tahoe	Body	HVAC Control Module Manual																																																										
C	2010	Tahoe	Body	Instrument Panel Cluster																																																										
C	2010	Tahoe	Body	Left Side Object Detection Module																																																										
C	2010	Tahoe	Body	Lift Gate Module																																																										
C	2010	Tahoe	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2010	Tahoe	Body	Park Assist Module																																																										
C	2010	Tahoe	Body	Passenger Door Switch																																																											
C	2010	Tahoe	Body	Passenger Presence System																																																											
C	2010	Tahoe	Body	Radio																																																										
C	2010	Tahoe	Body	Rear Heated Seat Module																																																											
C	2010	Tahoe	Body	Rear HVAC/RSA																																																											
C	2010	Tahoe	Body	Right Side Object Detection Module																																																											
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																											
C	2010	Tahoe	Body	Theft Deterrent Module																																																											
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2010	Tahoe Hybrid	Body	Body Control Module																																																											
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																																											
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																																											
C	2010	Tahoe Hybrid	Body	HVAC Control Module																																																											
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																																											
C	2010	Tahoe Hybrid	Body	Park Assist Module																																																											
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																											
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																																											
C	2010	Tahoe Hybrid	Body	Radio																																																											
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2011	Avalanche	Chassis	Electronic Brake Control Module																																																											
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																											
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2011	Avalanche	Body	Amplifier (Bose)																																																									
C	2011	Avalanche	Body	Assist Step Controller																																																									
C	2011	Avalanche	Body	Body Control Module																																																									
C	2011	Avalanche	Body	Body Control Module (aux.)																																																									
C	2011	Avalanche	Body	Digital Radio Receiver																																																									
C	2011	Avalanche	Body	Driver Door Switch																																																									
C	2011	Avalanche	Body	HVAC Control Module Auto																																																									
C	2011	Avalanche	Body	HVAC Control Module Manual																																																									
C	2011	Avalanche	Body	Instrument Panel Cluster																																																									
C	2011	Avalanche	Body	Memory Seat Module																																																									
C	2011	Avalanche	Body	Park Assist Module																																																									
C	2011	Avalanche	Body	Passenger Door Switch																																																									
C	2011	Avalanche	Body	Passenger Presence System																																																									
C	2011	Avalanche	Body	Radio																																																									
C	2011	Avalanche	Body	Rear Heated Seat Module																																																									
C	2011	Avalanche	Body	Rear HVAC/RSA																																																									
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																									
C	2011	Avalanche	Body	Theft Deterrent Module																																																									
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V																
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V	V			V																
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																									
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V																
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V	V			V																
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																									
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																									
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																									
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																									
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																									
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																									
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																									
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																									
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																									
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																									
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																									
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																									
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																									
C	2011	Captiva	Chassis	Electronic Brake Control Module																																																									
C	2011	Captiva	Chassis	Parking Brake Control Module																																																									
C	2011	Captiva	Body	Body Control Module																																																									
C	2011	Captiva	Body	Auxiliary Body Control Module																																																									
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2011	Captiva	Body	Instrument Cluster																																																									
C	2011	Captiva	Body	Headlamp Control Module																																																									
C	2011	Captiva	Body	HVAC Control Module																																																									
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																									
C	2011	Captiva	Body	Parking Assist Control Module																																																									
C	2011	Captiva	Body	Theft Deterrent Module																																																									
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																										
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Cheyenne	Body	Amplifier (Bose)																																																										
C	2011	Cheyenne	Body	Body Control Module																																																										
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2011	Cheyenne	Body	Digital Radio Receiver																																																										
C	2011	Cheyenne	Body	Driver Door Switch																																																										
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2011	Cheyenne	Body	Park Assist Module																																																										
C	2011	Cheyenne	Body	Passenger Door Switch																																																										
C	2011	Cheyenne	Body	Passenger Presence System																																																										
C	2011	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2011	Cheyenne	Body	Theft Deterrent Module																																																										
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2011	Suburban	Chassis	Electronic Suspension Control																																																										
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Suburban	Body	Amplifier (Bose)																																																										
C	2011	Suburban	Body	Assist Step Controller																																																										
C	2011	Suburban	Body	Body Control Module																																																										
C	2011	Suburban	Body	Body Control Module (aux.)																																																										
C	2011	Suburban	Body	Digital Radio Receiver																																																										
C	2011	Suburban	Body	Driver Door Switch																																																										
C	2011	Suburban	Body	HVAC Control Module Auto																																																										
C	2011	Suburban	Body	HVAC Control Module Manual																																																										
C	2011	Suburban	Body	Instrument Panel Cluster																																																										
C	2011	Suburban	Body	Left Side Object Detection Module																																																										
C	2011	Suburban	Body	Lift Gate Module																																																										
C	2011	Suburban	Body	Memory Seat Module																																																										
C	2011	Suburban	Body	Park Assist Module																																																										
C	2011	Suburban	Body	Passenger Door Switch																																																										
C	2011	Suburban	Body	Passenger Presence System																																																										
C	2011	Suburban	Body	Radio																																																										
C	2011	Suburban	Body	Rear Heated Seat Module																																																										
C	2011	Suburban	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2011	Suburban	Body	Right Side Object Detection Module																																																										
C	2011	Suburban	Body	Supplemental Inflatable Restraint																																																											
C	2011	Suburban	Body	Theft Deterrent Module																																																											
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																											
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																											
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module			V	V	V	V	V	V																			V								V		V												V	V			V	V		V
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																												V																															
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V								V		V												V	V			V	V		V
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																															
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																											
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2011	Silverado	Chassis	Electronic Suspension Control																																																											
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2011	Silverado	Body	Amplifier (Bose)																																																											
C	2011	Silverado	Body	Body Control Module																																																										
C	2011	Silverado	Body	Body Control Module (aux.)																																																										
C	2011	Silverado	Body	Digital Radio Receiver																																																										
C	2011	Silverado	Body	Driver Door Switch																																																										
C	2011	Silverado	Body	HVAC Control Module Auto																																																										
C	2011	Silverado	Body	HVAC Control Module Manual																																																										
C	2011	Silverado	Body	Instrument Panel Cluster																																																										
C	2011	Silverado	Body	Memory Seat Module																																																										
C	2011	Silverado	Body	Park Assist Module																																																										
C	2011	Silverado	Body	Passenger Door Switch																																																										
C	2011	Silverado	Body	Passenger Presence System																																																										
C	2011	Silverado	Body	Radio																																																										
C	2011	Silverado	Body	Rear Heated Seat Module																																																										
C	2011	Silverado	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2011	Silverado	Body	Theft Deterrent Module																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																											
C	2011	Silverado Hybrid	Body	Body Control Module																																																											
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																											
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																											
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																											
C	2011	Silverado Hybrid	Body	HVAC Control Module																																																											
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
C	2011	Silverado Hybrid	Body	Park Assist Module																																																											
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2011	Silverado Hybrid	Body	Passenger Presence System																																																											
C	2011	Silverado Hybrid	Body	Radio																																																											
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2011	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2011	Tahoe	Body	Amplifier (Bose)																																																											
C	2011	Tahoe	Body	Assist Step Controller																																																											
C	2011	Tahoe	Body	Body Control Module																																																											
C	2011	Tahoe	Body	Body Control Module (aux.)																																																											
C	2011	Tahoe	Body	Digital Radio Receiver																																																											
C	2011	Tahoe	Body	Driver Door Switch																																																											
C	2011	Tahoe	Body	HVAC Control Module Auto																																																											
C	2011	Tahoe	Body	HVAC Control Module Manual																																																											
C	2011	Tahoe	Body	Instrument Panel Cluster																																																											
C	2011	Tahoe	Body	Left Side Object Detection Module																																																											
C	2011	Tahoe	Body	Lift Gate Module																																																											
C	2011	Tahoe	Body	Memory Seat Module																																																											
C	2011	Tahoe	Body	Park Assist Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2011	Tahoe	Body	Passenger Door Switch																																																									
C	2011	Tahoe	Body	Passenger Presence System																																																									
C	2011	Tahoe	Body	Radio																																																									
C	2011	Tahoe	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe	Body	Right Side Object Detection Module																																																										
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2011	Tahoe	Body	Theft Deterrent Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Tahoe Hybrid	Body	Body Control Module																																																										
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2011	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2011	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2011	Tahoe Hybrid	Body	Radio																																																										
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2012	Avalanche	Body	Amplifier (Bose)																																																										
C	2012	Avalanche	Body	Assist Step Controller																																																										
C	2012	Avalanche	Body	Body Control Module																																																										
C	2012	Avalanche	Body	Body Control Module (aux.)																																																										
C	2012	Avalanche	Body	Digital Radio Receiver																																																										
C	2012	Avalanche	Body	Driver Door Switch																																																										
C	2012	Avalanche	Body	HVAC Control Module Auto																																																										
C	2012	Avalanche	Body	HVAC Control Module Manual																																																										
C	2012	Avalanche	Body	Instrument Panel Cluster																																																										
C	2012	Avalanche	Body	Memory Seat Module																																																										
C	2012	Avalanche	Body	Navigation Radio																																																										
C	2012	Avalanche	Body	Park Assist Module																																																										
C	2012	Avalanche	Body	Passenger Door Switch																																																										
C	2012	Avalanche	Body	Passenger Presence System																																																										
C	2012	Avalanche	Body	Radio																																																										
C	2012	Avalanche	Body	Rear Heated Seat Module																																																										
C	2012	Avalanche	Body	Rear HVAC/RSA																																																										
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2012	Avalanche	Body	Theft Deterrent Module																																																										
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																	
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																	
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																										
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2012	Captiva	Chassis	Parking Brake Control Module																																																										
C	2012	Captiva	Body	Body Control Module																																																										
C	2012	Captiva	Body	Auxiliary Body Control Module																																																										
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2012	Captiva	Body	Instrument Cluster																																																										
C	2012	Captiva	Body	Headlamp Control Module																																																										
C	2012	Captiva	Body	HVAC Control Module																																																										
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																										
C	2012	Captiva	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2012	Captiva	Body	Theft Deterrent Module																																																									
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																										
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Cheyenne	Body	Amplifier (Bose)																																																										
C	2012	Cheyenne	Body	Body Control Module																																																										
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2012	Cheyenne	Body	Digital Radio Receiver																																																										
C	2012	Cheyenne	Body	Driver Door Switch																																																										
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2012	Cheyenne	Body	Park Assist Module																																																										
C	2012	Cheyenne	Body	Passenger Door Switch																																																										
C	2012	Cheyenne	Body	Passenger Presence System																																																										
C	2012	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2012	Cheyenne	Body	Theft Deterrent Module																																																										
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																										
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2012	Suburban	Chassis	Electronic Suspension Control																																																										
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Suburban	Body	Amplifier (Bose)																																																										
C	2012	Suburban	Body	Assist Step Controller																																																										
C	2012	Suburban	Body	Body Control Module																																																										
C	2012	Suburban	Body	Body Control Module (aux.)																																																										
C	2012	Suburban	Body	Digital Radio Receiver																																																										
C	2012	Suburban	Body	Driver Door Switch																																																										
C	2012	Suburban	Body	HVAC Control Module Auto																																																										
C	2012	Suburban	Body	HVAC Control Module Manual																																																										
C	2012	Suburban	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2012	Suburban	Body	Left Side Object Detection Module																																																										
C	2012	Suburban	Body	Lift Gate Module																																																										
C	2012	Suburban	Body	Memory Seat Module																																																										
C	2012	Suburban	Body	Navigation Radio																																																										
C	2012	Suburban	Body	Park Assist Module																																																										
C	2012	Suburban	Body	Passenger Door Switch																																																										
C	2012	Suburban	Body	Passenger Presence System																																																										
C	2012	Suburban	Body	Radio																																																										
C	2012	Suburban	Body	Rear Heated Seat Module																																																										
C	2012	Suburban	Body	Rear HVAC/RSA																																																										
C	2012	Suburban	Body	Right Side Object Detection Module																																																										
C	2012	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2012	Suburban	Body	Theft Deterrent Module																																																										
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																										
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V												V	V			V	V		V
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																												V																														
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V												V	V			V	V		V
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																														
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2012	Silverado	Chassis	Electronic Suspension Control																																																										
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2012	Silverado	Body	Amplifier (Bose)																																																										
C	2012	Silverado	Body	Body Control Module																																																										
C	2012	Silverado	Body	Body Control Module (aux.)																																																										
C	2012	Silverado	Body	Digital Radio Receiver																																																										
C	2012	Silverado	Body	Driver Door Switch																																																										
C	2012	Silverado	Body	HVAC Control Module Auto																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2012	Silverado	Body	HVAC Control Module Manual																																																										
C	2012	Silverado	Body	Instrument Panel Cluster																																																											
C	2012	Silverado	Body	Memory Seat Module																																																											
C	2012	Silverado	Body	Navigation Radio																																																											
C	2012	Silverado	Body	Park Assist Module																																																											
C	2012	Silverado	Body	Passenger Door Switch																																																											
C	2012	Silverado	Body	Passenger Presence System																																																											
C	2012	Silverado	Body	Radio																																																											
C	2012	Silverado	Body	Rear Heated Seat Module																																																											
C	2012	Silverado	Body	Rear HVAC/RSA																																																											
C	2012	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2012	Silverado	Body	Theft Deterrent Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																											
C	2012	Silverado Hybrid	Body	Body Control Module																																																											
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																											
C	2012	Silverado Hybrid	Body	Driver Door Switch																																																											
C	2012	Silverado Hybrid	Body	Heated Seat Module																																																											
C	2012	Silverado Hybrid	Body	HVAC Control Module																																																											
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
C	2012	Silverado Hybrid	Body	Navigation Radio																																																											
C	2012	Silverado Hybrid	Body	Park Assist Module																																																											
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2012	Silverado Hybrid	Body	Passenger Presence System																																																											
C	2012	Silverado Hybrid	Body	Radio																																																											
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2012	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2012	Tahoe	Body	Amplifier (Bose)																																																											
C	2012	Tahoe	Body	Assist Step Controller																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2012	Tahoe	Body	Body Control Module																																																										
C	2012	Tahoe	Body	Body Control Module (aux.)																																																											
C	2012	Tahoe	Body	Digital Radio Receiver																																																											
C	2012	Tahoe	Body	Driver Door Switch																																																											
C	2012	Tahoe	Body	HVAC Control Module Auto																																																											
C	2012	Tahoe	Body	HVAC Control Module Manual																																																											
C	2012	Tahoe	Body	Instrument Panel Cluster																																																											
C	2012	Tahoe	Body	Left Side Object Detection Module																																																											
C	2012	Tahoe	Body	Lift Gate Module																																																											
C	2012	Tahoe	Body	Memory Seat Module																																																											
C	2012	Tahoe	Body	Navigation Radio																																																											
C	2012	Tahoe	Body	Park Assist Module																																																											
C	2012	Tahoe	Body	Passenger Door Switch																																																											
C	2012	Tahoe	Body	Passenger Presence System																																																											
C	2012	Tahoe	Body	Radio																																																											
C	2012	Tahoe	Body	Rear Heated Seat Module																																																											
C	2012	Tahoe	Body	Rear HVAC/RSA																																																											
C	2012	Tahoe	Body	Right Side Object Detection Module																																																											
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																											
C	2012	Tahoe	Body	Theft Deterrent Module																																																											
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2012	Tahoe Hybrid	Body	Body Control Module																																																											
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																																											
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																																											
C	2012	Tahoe Hybrid	Body	HVAC Control Module																																																											
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
C	2012	Tahoe Hybrid	Body	Lift Gate Module																																																											
C	2012	Tahoe Hybrid	Body	Navigation Radio																																																											
C	2012	Tahoe Hybrid	Body	Park Assist Module																																																											
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																											
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																																											
C	2012	Tahoe Hybrid	Body	Radio																																																											
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Avalanche	Body	Amplifier (Bose)																																																										
C	2013	Avalanche	Body	Assist Step Controller																																																										
C	2013	Avalanche	Body	Body Control Module																																																										
C	2013	Avalanche	Body	Body Control Module (aux.)																																																										
C	2013	Avalanche	Body	Digital Radio Receiver																																																										
C	2013	Avalanche	Body	Driver Door Switch																																																										
C	2013	Avalanche	Body	HVAC Control Module Auto																																																										
C	2013	Avalanche	Body	HVAC Control Module Manual																																																										
C	2013	Avalanche	Body	Instrument Panel Cluster																																																										
C	2013	Avalanche	Body	Memory Seat Module																																																										
C	2013	Avalanche	Body	Navigation Radio																																																										
C	2013	Avalanche	Body	Park Assist Module																																																										
C	2013	Avalanche	Body	Passenger Door Switch																																																										
C	2013	Avalanche	Body	Passenger Presence System																																																										
C	2013	Avalanche	Body	Radio																																																										
C	2013	Avalanche	Body	Rear Heated Seat Module																																																										
C	2013	Avalanche	Body	Rear HVAC/RSA																																																										
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2013	Avalanche	Body	Theft Deterrent Module																																																										
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																		
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																		
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																		
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																		
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2013	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2013	Captiva	Chassis	Parking Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																										
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																										
C	2013	Captiva	Body	Auxiliary Body Control Module																																																										
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2013	Captiva	Body	Instrument Cluster																																																										
C	2013	Captiva	Body	Headlamp Control Module																																																										
C	2013	Captiva	Body	HVAC Control Module																																																										
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
C	2013	Captiva	Body	Theft Deterrent Module																																																										
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																										
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Cheyenne	Body	Amplifier (Bose)																																																										
C	2013	Cheyenne	Body	Body Control Module																																																										
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2013	Cheyenne	Body	Digital Radio Receiver																																																										
C	2013	Cheyenne	Body	Driver Door Switch																																																										
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2013	Cheyenne	Body	Park Assist Module																																																										
C	2013	Cheyenne	Body	Passenger Door Switch																																																										
C	2013	Cheyenne	Body	Passenger Presence System																																																										
C	2013	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2013	Cheyenne	Body	Theft Deterrent Module																																																										
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																										
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2013	Suburban	Chassis	Electronic Suspension Control																																																										
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Suburban	Body	Amplifier (Bose)																																																											
C	2013	Suburban	Body	Assist Step Controller																																																											
C	2013	Suburban	Body	Body Control Module																																																											
C	2013	Suburban	Body	Body Control Module (aux.)																																																											
C	2013	Suburban	Body	Digital Radio Receiver																																																											
C	2013	Suburban	Body	Driver Door Switch																																																											
C	2013	Suburban	Body	HVAC Control Module Auto																																																											
C	2013	Suburban	Body	HVAC Control Module Manual																																																											
C	2013	Suburban	Body	Instrument Panel Cluster																																																											
C	2013	Suburban	Body	Left Side Object Detection Module																																																											
C	2013	Suburban	Body	Lift Gate Module																																																											
C	2013	Suburban	Body	Memory Seat Module																																																											
C	2013	Suburban	Body	Navigation Radio																																																											
C	2013	Suburban	Body	Park Assist Module																																																											
C	2013	Suburban	Body	Passenger Door Switch																																																											
C	2013	Suburban	Body	Passenger Presence System																																																											
C	2013	Suburban	Body	Radio																																																											
C	2013	Suburban	Body	Rear Heated Seat Module																																																											
C	2013	Suburban	Body	Rear HVAC/RSA																																																											
C	2013	Suburban	Body	Right Side Object Detection Module																																																											
C	2013	Suburban	Body	Supplemental Inflatable Restraint																																																											
C	2013	Suburban	Body	Theft Deterrent Module																																																											
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																											
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																											
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																											
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V																				V							V		V											V	V			V	V		V
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																												V																														
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2013	Silverado	Chassis	Electronic Suspension Control																																																											
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2013	Silverado	Body	Amplifier (Bose)																																																											
C	2013	Silverado	Body	Body Control Module																																																											
C	2013	Silverado	Body	Body Control Module (aux.)																																																											
C	2013	Silverado	Body	Digital Radio Receiver																																																											
C	2013	Silverado	Body	Driver Door Switch																																																											
C	2013	Silverado	Body	HVAC Control Module Auto																																																											
C	2013	Silverado	Body	HVAC Control Module Manual																																																											
C	2013	Silverado	Body	Instrument Panel Cluster																																																											
C	2013	Silverado	Body	Memory Seat Module																																																											
C	2013	Silverado	Body	Navigation Radio																																																											
C	2013	Silverado	Body	Park Assist Module																																																											
C	2013	Silverado	Body	Passenger Door Switch																																																											
C	2013	Silverado	Body	Passenger Presence System																																																											
C	2013	Silverado	Body	Radio																																																											
C	2013	Silverado	Body	Rear Heated Seat Module																																																											
C	2013	Silverado	Body	Rear HVAC/RSA																																																											
C	2013	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2013	Silverado	Body	Theft Deterrent Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																											
C	2013	Silverado Hybrid	Body	Body Control Module																																																											
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																											
C	2013	Silverado Hybrid	Body	Driver Door Switch																																																											
C	2013	Silverado Hybrid	Body	Heated Seat Module																																																											
C	2013	Silverado Hybrid	Body	HVAC Control Module																																																											
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
C	2013	Silverado Hybrid	Body	Navigation Radio																																																											
C	2013	Silverado Hybrid	Body	Park Assist Module																																																											
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2013	Silverado Hybrid	Body	Passenger Presence System																																																											
C	2013	Silverado Hybrid	Body	Radio																																																											
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																										
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Tahoe	Body	Amplifier (Bose)																																																										
C	2013	Tahoe	Body	Assist Step Controller																																																										
C	2013	Tahoe	Body	Body Control Module																																																										
C	2013	Tahoe	Body	Body Control Module (aux.)																																																										
C	2013	Tahoe	Body	Digital Radio Receiver																																																										
C	2013	Tahoe	Body	Driver Door Switch																																																										
C	2013	Tahoe	Body	HVAC Control Module Auto																																																										
C	2013	Tahoe	Body	HVAC Control Module Manual																																																										
C	2013	Tahoe	Body	Instrument Panel Cluster																																																										
C	2013	Tahoe	Body	Left Side Object Detection Module																																																										
C	2013	Tahoe	Body	Lift Gate Module																																																										
C	2013	Tahoe	Body	Memory Seat Module																																																										
C	2013	Tahoe	Body	Navigation Radio																																																										
C	2013	Tahoe	Body	Park Assist Module																																																										
C	2013	Tahoe	Body	Passenger Door Switch																																																										
C	2013	Tahoe	Body	Passenger Presence System																																																										
C	2013	Tahoe	Body	Radio																																																										
C	2013	Tahoe	Body	Rear Heated Seat Module																																																										
C	2013	Tahoe	Body	Rear HVAC/RSA																																																										
C	2013	Tahoe	Body	Right Side Object Detection Module																																																										
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2013	Tahoe	Body	Theft Deterrent Module																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2013	Tahoe Hybrid	Body	Body Control Module																																																										
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2013	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2013	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2013	Tahoe Hybrid	Body	Navigation Radio																																																										
C	2013	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2013	Tahoe Hybrid	Body	Radio																																																										
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
C	2014	Captiva (3GN)	Body	Body Control Module																																																										
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Captiva (3GN)	Body	Passenger Presence Module																																																										
C	2014	Captiva (3GN)	Body	Instrument Cluster																																																										
C	2014	Captiva (3GN)	Body	Radio																																																										
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Captiva (3GN)	Body	HVAC Control Module																																																										
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																										
C	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																	
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																	
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																										
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Captiva (Other)	Body	Instrument Cluster																																																										
C	2014	Captiva (Other)	Body	Headlamp Control Module																																																										
C	2014	Captiva (Other)	Body	HVAC Control Module																																																										
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
C	2014	Captiva (Other)	Body	Theft Deterrent Module																																																										
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																										
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																										
C	2014	Cheyenne	Chassis	Power Steering Control Module																																																										
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Cheyenne	Body	Body Control Module																																																										
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Cheyenne	Body	Passenger Presence Module																																																										
C	2014	Cheyenne	Body	Instrument Cluster																																																										
C	2014	Cheyenne	Body	Radio Control																																																										
C	2014	Cheyenne	Body	HVAC Control																																																										
C	2014	Cheyenne	Body	Radio																																																										
C	2014	Cheyenne	Body	Amplifier																																																										
C	2014	Cheyenne	Body	Media Disc Player																																																										
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																										
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
C	2014	Cheyenne	Body	HVAC Control Module																																																										
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																										
C	2014	Cheyenne	Body	Parking Assist Control Module																																																										
C	2014	Cheyenne	Body	Frontview Camera Module																																																										
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado	Chassis	Parking Brake Control Module																																																										
C	2014	Silverado	Chassis	Power Steering Control Module																																																										
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Silverado	Body	Body Control Module																																																										
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado	Body	Passenger Presence Module																																																										
C	2014	Silverado	Body	Instrument Cluster																																																										
C	2014	Silverado	Body	Radio Control																																																										
C	2014	Silverado	Body	HVAC Control																																																										
C	2014	Silverado	Body	Radio																																																										
C	2014	Silverado	Body	Amplifier																																																										
C	2014	Silverado	Body	Media Disc Player																																																										
C	2014	Silverado	Body	Human Machine Interface Control Module																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2014	Silverado	Body	Parking Assist Control Module																																																										
C	2014	Silverado	Body	Frontview Camera Module																																																										
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																	V		V								V							V	V	V	V
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																											V																															
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																										
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Suspension Control Module																																																										
C	2014	Silverado HD	Body	Body Control Module																																																										
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado HD	Body	Passenger Presence Module																																																										
C	2014	Silverado HD	Body	Instrument Cluster																																																										
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
C	2014	Silverado HD	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2014	Silverado HD	Body	Navigation Radio																																																										
C	2014	Silverado HD	Body	Uplevel Radio																																																										
C	2014	Silverado HD	Body	Amplifier																																																										
C	2014	Silverado HD	Body	Rear Audio Control Module																																																										
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																										
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																										
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Silverado HD	Body	Seat Memory Control Module																																																										
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																										
C	2014	Silverado HD	Body	Parking Assist Control Module																																																										
C	2014	Silverado HD	Body	Theft Deterrent Module																																																										
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																										
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2014	Suburban	Chassis	Parking Brake Control Module																																																										
C	2014	Suburban	Chassis	Suspension Control Module																																																										
C	2014	Suburban	Body	Body Control Module																																																										
C	2014	Suburban	Body	Auxiliary Body Control Module																																																										
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Suburban	Body	Passenger Presence Module																																																										
C	2014	Suburban	Body	Instrument Cluster																																																										
C	2014	Suburban	Body	Base Radio																																																										
C	2014	Suburban	Body	Navigation Radio																																																										
C	2014	Suburban	Body	Uplevel Radio																																																										
C	2014	Suburban	Body	Amplifier																																																										
C	2014	Suburban	Body	Rear Audio Control Module																																																										
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																										
C	2014	Suburban	Body	Personal Audio Link Control Module																																																										
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Suburban	Body	Liftgate Control Module																																																										
C	2014	Suburban	Body	Seat Memory Control Module																																																										
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2014	Suburban	Body	Assist Step Control Module																																																									
C	2014	Suburban	Body	Right Side Object Detection Control Module																																																										
C	2014	Suburban	Body	Left Side Object Detection Control Module																																																										
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																										
C	2014	Suburban	Body	Parking Assist Control Module																																																										
C	2014	Suburban	Body	Theft Deterrent Module																																																										
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																										
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																										
C	2014	Tahoe	Chassis	Suspension Control Module																																																										
C	2014	Tahoe	Body	Body Control Module																																																										
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																										
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Tahoe	Body	Passenger Presence Module																																																										
C	2014	Tahoe	Body	Instrument Cluster																																																										
C	2014	Tahoe	Body	Base Radio																																																										
C	2014	Tahoe	Body	Navigation Radio																																																										
C	2014	Tahoe	Body	Uplevel Radio																																																										
C	2014	Tahoe	Body	Amplifier																																																										
C	2014	Tahoe	Body	Rear Audio Control Module																																																										
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																										
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																										
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Tahoe	Body	Liftgate Control Module																																																										
C	2014	Tahoe	Body	Seat Memory Control Module																																																										
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																																										
C	2014	Tahoe	Body	Assist Step Control Module																																																										
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																																										
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																																										
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																										
C	2014	Tahoe	Body	Parking Assist Control Module																																																										
C	2014	Tahoe	Body	Theft Deterrent Module																																																										
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2015	Captiva (3GN)	Body	Body Control Module																																																										
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																																											
C	2015	Captiva (3GN)	Body	Instrument Cluster																																																											
C	2015	Captiva (3GN)	Body	Radio																																																											
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																											
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																											
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																											
C	2015	Captiva (3GN)	Body	HVAC Control Module																																																											
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																											
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																											
C	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																											
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																		
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																		
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																		
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																		
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																											
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																											
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																											
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																											
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Captiva (Other)	Body	Instrument Cluster																																																											
C	2015	Captiva (Other)	Body	Headlamp Control Module																																																											
C	2015	Captiva (Other)	Body	HVAC Control Module																																																											
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
C	2015	Captiva (Other)	Body	Theft Deterrent Module																																																											
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																											
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																									
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																										
C	2015	Cheyenne	Chassis	Power Steering Control Module																																																										
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Cheyenne	Chassis	Suspension Control Module																																																										
C	2015	Cheyenne	Body	Body Control Module																				V																							V															
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Cheyenne	Body	Passenger Presence Module																																																										
C	2015	Cheyenne	Body	Instrument Cluster																																																										
C	2015	Cheyenne	Body	Radio Controls																																																										
C	2015	Cheyenne	Body	HVAC Controls																																																										
C	2015	Cheyenne	Body	Radio																																																										
C	2015	Cheyenne	Body	Amplifier																																																										
C	2015	Cheyenne	Body	Media Disc Player																																																										
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																										
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
C	2015	Cheyenne	Body	HVAC Control Module																																																										
C	2015	Cheyenne	Body	Parking Assist Control Module																																																										
C	2015	Cheyenne	Body	Frontview Camera Module																																																										
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																		V		V								V								V	V	V	V
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																											V																															
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Silverado	Chassis	Power Steering Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Silverado	Chassis	Suspension Control Module																																																											
C	2015	Silverado	Body	Body Control Module																				V																								V															
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Silverado	Body	Passenger Presence Module																																																											
C	2015	Silverado	Body	Instrument Cluster																																																											
C	2015	Silverado	Body	Radio Controls																																																											
C	2015	Silverado	Body	HVAC Controls																																																											
C	2015	Silverado	Body	Radio																																																											
C	2015	Silverado	Body	Amplifier																																																											
C	2015	Silverado	Body	Media Disc Player																																																											
C	2015	Silverado	Body	Human Machine Interface Control Module																																																											
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																											
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
C	2015	Silverado	Body	Parking Assist Control Module																																																											
C	2015	Silverado	Body	Frontview Camera Module																																																											
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																											
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2015	Suburban	Chassis	Electronic Brake Control Module																																																											
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																											
C	2015	Suburban	Chassis	Parking Brake Control Module																																																											
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2015	Suburban	Chassis	Power Steering Control Module																																																											
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Suburban	Chassis	Suspension Control Module																																																											
C	2015	Suburban	Body	Body Control Module																																																											
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Suburban	Body	Passenger Presence Module																																																											
C	2015	Suburban	Body	Instrument Cluster																																																											
C	2015	Suburban	Body	Radio Controls																																																										
C	2015	Suburban	Body	HVAC Controls																																																										
C	2015	Suburban	Body	Radio																																																										
C	2015	Suburban	Body	Amplifier																																																										
C	2015	Suburban	Body	Media Disc Player																																																										
C	2015	Suburban	Body	Human Machine Interface Control Module																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Suburban	Body	HVAC Control Module																																																										
C	2015	Suburban	Body	Liftgate Control Module																																																										
C	2015	Suburban	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2015	Suburban	Body	Assist Step Control Module																																																										
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																											
C	2015	Suburban	Body	Parking Assist Control Module																																																											
C	2015	Suburban	Body	Frontview Camera Module																																																											
C	2015	Suburban	Body	Steering Column Lock Control Module																																																											
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																											
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																											
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																											
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																											
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																											
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																											
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																											
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2015	Tahoe	Chassis	Power Steering Control Module																																																											
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Tahoe	Chassis	Suspension Control Module																																																											
C	2015	Tahoe	Body	Body Control Module																																																											
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Tahoe	Body	Passenger Presence Module																																																											
C	2015	Tahoe	Body	Instrument Cluster																																																											
C	2015	Tahoe	Body	Radio Controls																																																											
C	2015	Tahoe	Body	HVAC Controls																																																											
C	2015	Tahoe	Body	Radio																																																											
C	2015	Tahoe	Body	Amplifier																																																											
C	2015	Tahoe	Body	Media Disc Player																																																											
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																											
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																											
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																											
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2015	Tahoe	Body	HVAC Control Module																																																											
C	2015	Tahoe	Body	Liftgate Control Module																																																											
C	2015	Tahoe	Body	Keyless Entry Control Module																																																											
C	2015	Tahoe	Body	Assist Step Control Module																																																											
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																											
C	2015	Tahoe	Body	Parking Assist Control Module																																																											
C	2015	Tahoe	Body	Frontview Camera Module																																																											
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																											
C	2015	Tahoe	Body	Battery Energy Control Module																																																											
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																							
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																							
C	2016	Captiva (3GN)	Body	Body Control Module																																																							
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																							
C	2016	Captiva (3GN)	Body	Radio																																																							
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																							
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																							
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																							
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																							
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																							
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																							
C	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																							
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																														V			V	V									V	V				V					V
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																														V			V	V									V	V				V					V
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																						
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V													
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V	V			V													
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																						
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V													
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V	V			V													
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																						
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																						
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																						
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																						
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																						
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																						
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																						
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																						
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																						
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																						
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																						
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																						
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																						
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																						
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																						
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
C	2016	Captiva (Other)	Body	Instrument Cluster																																																						
C	2016	Captiva (Other)	Body	Headlamp Control Module																																																						
C	2016	Captiva (Other)	Body	Radio																																																						
C	2016	Captiva (Other)	Body	HVAC Control Module																																																						
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																						
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																						
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																						
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																						
C	2016	Captiva (Other)	Body	Theft Deterrent Module																																																						
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																						
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																						
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																						
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																						
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																						

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																									
C	2016	Cheyenne	Chassis	Power Steering Control Module																																																									
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2016	Cheyenne	Chassis	Suspension Control Module																																																									
C	2016	Cheyenne	Body	Body Control Module																																																									
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Cheyenne	Body	Passenger Presence Module																																																									
C	2016	Cheyenne	Body	Instrument Cluster																																																									
C	2016	Cheyenne	Body	Radio Controls																																																									
C	2016	Cheyenne	Body	HVAC Controls																																																									
C	2016	Cheyenne	Body	Radio																																																									
C	2016	Cheyenne	Body	Amplifier																																																									
C	2016	Cheyenne	Body	Media Disc Player																																																									
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																									
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																									
C	2016	Cheyenne	Body	HVAC Control Module																																																									
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																									
C	2016	Cheyenne	Body	Parking Assist Control Module																																																									
C	2016	Cheyenne	Body	Frontview Camera Module																																																									
C	2016	Cheyenne	Body	Frontview Camera Module																																																									
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																									
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																									
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																									
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																									
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																									
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																	V		V							V							V	V	V	V
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																											V																													
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																									
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2016	Silverado	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2016	Silverado	Chassis	Power Steering Control Module																																																										
C	2016	Silverado	Chassis	Power Steering Control Module																																																											
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Silverado	Chassis	Suspension Control Module																																																											
C	2016	Silverado	Body	Body Control Module																																																											
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Silverado	Body	Passenger Presence Module																																																											
C	2016	Silverado	Body	Instrument Cluster																																																											
C	2016	Silverado	Body	Radio Controls																																																											
C	2016	Silverado	Body	HVAC Controls																																																											
C	2016	Silverado	Body	Radio (IO3)																																																											
C	2016	Silverado	Body	Radio (IOB)																																																											
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																											
C	2016	Silverado	Body	Amplifier																																																											
C	2016	Silverado	Body	Media Disc Player																																																											
C	2016	Silverado	Body	Human Machine Interface Control Module																																																											
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																											
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																											
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																											
C	2016	Silverado	Body	Parking Assist Control Module																																																											
C	2016	Silverado	Body	Frontview Camera Module																																																											
C	2016	Silverado	Body	Frontview Camera Module																																																											
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2016	Suburban	Chassis	Electronic Brake Control Module																																																											
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																											
C	2016	Suburban	Chassis	Parking Brake Control Module																																																											
C	2016	Suburban	Chassis	Power Steering Control Module																																																											
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Suburban	Chassis	Suspension Control Module																																																											
C	2016	Suburban	Body	Body Control Module																																																											
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Suburban	Body	Passenger Presence Module																																																											
C	2016	Suburban	Body	Instrument Cluster																																																											
C	2016	Suburban	Body	Radio Controls																																																											
C	2016	Suburban	Body	HVAC Controls																																																											
C	2016	Suburban	Body	Radio																																																											
C	2016	Suburban	Body	Amplifier																																																											
C	2016	Suburban	Body	Media Disc Player																																																											
C	2016	Suburban	Body	Human Machine Interface Control Module																																																											
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																																											
C	2016	Suburban	Body	HVAC Control Module																																																											
C	2016	Suburban	Body	Liftgate Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																									
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																										
C	2016	Suburban	Body	Keyless Entry Control Module																																																										
C	2016	Suburban	Body	Assist Step Control Module																																																										
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																										
C	2016	Suburban	Body	Parking Assist Control Module																																																										
C	2016	Suburban	Body	Frontview Camera Module																																																										
C	2016	Suburban	Body	Steering Column Lock Control Module																																																										
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																										
C	2016	Tahoe	Chassis	Power Steering Control Module																																																										
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Tahoe	Chassis	Suspension Control Module																																																										
C	2016	Tahoe	Body	Body Control Module																																																										
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Tahoe	Body	Passenger Presence Module																																																										
C	2016	Tahoe	Body	Instrument Cluster																																																										
C	2016	Tahoe	Body	Radio Controls																																																										
C	2016	Tahoe	Body	HVAC Controls																																																										
C	2016	Tahoe	Body	Radio																																																										
C	2016	Tahoe	Body	Amplifier																																																										
C	2016	Tahoe	Body	Media Disc Player																																																										
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																										
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																										
C	2016	Tahoe	Body	HVAC Control Module																																																										
C	2016	Tahoe	Body	Liftgate Control Module																																																										
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																										
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																										
C	2016	Tahoe	Body	Keyless Entry Control Module																																																										
C	2016	Tahoe	Body	Assist Step Control Module																																																										
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																										
C	2016	Tahoe	Body	Parking Assist Control Module																																																										
C	2016	Tahoe	Body	Frontview Camera Module																																																										
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																										
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																										
E	2004	ALL	Chassis	Electronic Brake Control Module																																																										
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2006	ALL	Chassis	Electronic Brake Control Module																																																										
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2007	ALL	Chassis	Electronic Brake Control Module																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																									
G	2004	Express/Savana	Body	Body Control Module																																																									
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2004	Express/Savana	Body	OnStar																																																									
G	2004	Express/Savana	Body	Base Radio																																																									
G	2004	Express/Savana	Body	Uplevel Radio																																																									
G	2004	Express/Savana	Body	Remote Function Actuation																																																									
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																																										
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2005	Express/Savana	Chassis	VSES																																																										
G	2005	Express/Savana	Body	Body Control Module																																																										
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2005	Express/Savana	Body	Base Radio																																																										
G	2005	Express/Savana	Body	Uplevel Radio																																																										
G	2005	Express/Savana	Body	Remote Function Actuation																																																										
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2005	Express Access/Savana Pro	Chassis	VSES																																																										
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2005	Express Access/Savana Pro	Body	Base Radio																																																										
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								V			
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2006	Express/Savana	Chassis	VSES																																																									
G	2006	Express/Savana	Body	Body Control Module																																																									
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2006	Express/Savana	Body	Passenger Presence System																																																									
G	2006	Express/Savana	Body	Base Radio																																																									
G	2006	Express/Savana	Body	Uplevel Radio																																																									
G	2006	Express/Savana	Body	Remote Function Actuation																																																									
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								V			
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2006	Express Access/Savana Pro	Chassis	VSES																																																									
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2006	Express Access/Savana Pro	Body	Base Radio																																																									
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																							V	
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																											V																													
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2007	Express/Savana	Body	Body Control Module																																																								
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2007	Express/Savana	Body	Passenger Presence System																																																								
G	2007	Express/Savana	Body	Base Radio																																																								
G	2007	Express/Savana	Body	Uplevel Radio																																																								
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																					V			
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																												V																													
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2007	Express Access/Savana Pro	Body	Radio																																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V									V				V						
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																													
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2008	Express/Savana	Body	Body Control Module																																																								
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2008	Express/Savana	Body	Passenger Presence System																																																								
G	2008	Express/Savana	Body	Radio																																																								
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2008	Express/Savana	Body	Rollover Sensor																																																								
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2008	Express/Savana	Body	Theft Deterrent Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V										V				V				
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																													
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2008	Express Access/Savana Pro	Body	Radio																																																								
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V										V				V				
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																													
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2009	Express/Savana	Body	Body Control Module																																																								
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2009	Express/Savana	Body	Passenger Presence System																																																								
G	2009	Express/Savana	Body	Radio																																																								
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2009	Express/Savana	Body	Rollover Sensor																																																								
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2009	Express/Savana	Body	Theft Deterrent Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V										V				V				
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																													
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2009	Express Access/Savana Pro	Body	Radio																																																								
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V												V	V		V	V		V
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																										V									V												V			V					
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																												V																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2010	Express/Savana	Body	Body Control Module																																																								
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2010	Express/Savana	Body	Passenger Presence System																																																								
G	2010	Express/Savana	Body	Radio																																																								
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2010	Express/Savana	Body	Rollover Sensor																																																								
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2010	Express/Savana	Body	Theft Deterrent Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V												V	V		V	V		V
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																										V									V												V				V		
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																												V																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																						
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																						
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																						
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																						
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																						
G	2010	Express Access/Savana Pro	Body	Radio																																																						
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																						
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																						
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																						
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																						
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																						
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																						
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																						
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																						
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																						
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																						
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																						
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																						
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V											V	V	V			V	V		V
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																											
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																						
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																						
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																						
G	2011	Express/Savana	Body	Body Control Module																																																						
G	2011	Express/Savana	Body	Digital Radio Receiver																																																						
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																						
G	2011	Express/Savana	Body	Passenger Presence System																																																						
G	2011	Express/Savana	Body	Radio																																																						
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
G	2011	Express/Savana	Body	Rollover Sensor																																																						
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																						
G	2011	Express/Savana	Body	Theft Deterrent Module																																																						
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																						
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																						
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																						
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																						
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																						
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																						
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																						
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																						
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																						
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V								V		V												V	V			V	V		V
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																												
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																							
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2011	Express Access/Savana Pro	Body	Body Control Module																																																							
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																							
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																							
G	2011	Express Access/Savana Pro	Body	Radio																																																							
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																							
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																							
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																							
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																							
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																							
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																							
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																							
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																							
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V								V		V												V	V			V	V		V
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																												
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																							
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2012	Express/Savana	Body	Body Control Module																																																							
G	2012	Express/Savana	Body	Digital Radio Receiver																																																							
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2012	Express/Savana	Body	Passenger Presence System																																																							
G	2012	Express/Savana	Body	Radio																																																							
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
G	2012	Express/Savana	Body	Rollover Sensor																																																							
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																							
G	2012	Express/Savana	Body	Theft Deterrent Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V								V		V											V	V			V	V		V
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																														
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2012	Express Access/Savana Pro	Body	Radio																																																										
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V																				V								V		V											V	V			V	V		V
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																														
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2013	Express/Savana	Body	Body Control Module																																																										
G	2013	Express/Savana	Body	Digital Radio Receiver																																																										
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2013	Express/Savana	Body	Navigation Radio																																																										
G	2013	Express/Savana	Body	Park Assist Module																																																										
G	2013	Express/Savana	Body	Passenger Presence System																																																										
G	2013	Express/Savana	Body	Radio																																																										
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2013	Express/Savana	Body	Rollover Sensor																																																										
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2013	Express/Savana	Body	Theft Deterrent Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V																			V							V		V												V	V		V	V		V
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																											V																													
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2013	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																								
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																								
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2013	Express Access/Savana Pro	Body	Radio																																																								
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																								
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																								
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																								
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																								
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																								
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																								
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																								
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V									V						V	V	V	V
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																											V																													
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2014	Express	Chassis	Electronic Brake Control Module																																																								
G	2014	Express	Body	Body Control Module																																																								
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
G	2014	Express	Body	Passenger Presence Module																																																								
G	2014	Express	Body	Rollover Sensor Module																																																								
G	2014	Express	Body	Instrument Cluster																																																								
G	2014	Express	Body	Chime Alarm Control Module																																																								
G	2014	Express	Body	Base Radio																																																								
G	2014	Express	Body	Navigation Radio																																																								
G	2014	Express	Body	Uplevel Radio																																																								
G	2014	Express	Body	Digital Radio Receiver Control Module																																																								
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																								
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																								
G	2014	Express	Body	Auxiliary Heater Control Module																																																								
G	2014	Express	Body	Remote Control Door Lock Receiver																																																								
G	2014	Express	Body	Parking Assist Control Module																																																								
G	2014	Express	Body	Theft Deterrent Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																							
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																							
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																							
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																						
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																						
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																						
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																						
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																						
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																						
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																						
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																						
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																	V		V								V						V	V	V	V
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																											V																											
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																						
G	2014	Savana	Chassis	Electronic Brake Control Module																																																						
G	2014	Savana	Body	Body Control Module																																																						
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
G	2014	Savana	Body	Passenger Presence Module																																																						
G	2014	Savana	Body	Rollover Sensor Module																																																						
G	2014	Savana	Body	Instrument Cluster																																																						
G	2014	Savana	Body	Chime Alarm Control Module																																																						
G	2014	Savana	Body	Base Radio																																																						
G	2014	Savana	Body	Navigation Radio																																																						
G	2014	Savana	Body	Uplevel Radio																																																						
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																						
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																						
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																						
G	2014	Savana	Body	Auxiliary Heater Control Module																																																						
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																						
G	2014	Savana	Body	Parking Assist Control Module																																																					
G	2014	Savana	Body	Theft Deterrent Module																																																					
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																						
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																						
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																						
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																						
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																						
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																						
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																	V		V								V						V	V	V	V
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																											V																											
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																						
G	2015	Express	Chassis	Electronic Brake Control Module																																																						
G	2015	Express	Body	Body Control Module																																																						
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
G	2015	Express	Body	Rollover Sensor Module																																																						
G	2015	Express	Body	Instrument Cluster																																																						
G	2015	Express	Body	Digital Radio Receiver Control Module																																																						
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																						
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																						
G	2015	Express	Body	Auxiliary Heater Control Module																																																						
G	2015	Express	Body	Remote Control Door Lock Receiver																																																						
G	2015	Express	Body	Parking Assist Control Module																																																						

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2015	Express	Body	Theft Deterrent Module																																																								
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V								V						V	V	V	V
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																												V																												
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2015	Savana	Chassis	Electronic Brake Control Module																																																								
G	2015	Savana	Body	Body Control Module																																																								
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
G	2015	Savana	Body	Rollover Sensor Module																																																								
G	2015	Savana	Body	Instrument Cluster																																																								
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																								
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																								
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																								
G	2015	Savana	Body	Auxiliary Heater Control Module																																																								
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																								
G	2015	Savana	Body	Parking Assist Control Module																																																								
G	2015	Savana	Body	Theft Deterrent Module																																																								
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V								V						V	V	V	V
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																												V																												
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2016	Express	Chassis	Electronic Brake Control Module																																																								
G	2016	Express	Body	Body Control Module																																																								
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
G	2016	Express	Body	Instrument Cluster																																																								
G	2016	Express	Body	Chime Alarm Control Module																																																								
G	2016	Express	Body	Base Radio																																																								
G	2016	Express	Body	Navigation Radio																																																								
G	2016	Express	Body	Uplevel Radio																																																								
G	2016	Express	Body	Digital Radio Receiver Control Module																																																								
G	2016	Express	Body	Telematics Communication Interface Control Module																																																								
G	2016	Express	Body	Auxiliary Heater Control Module																																																								
G	2016	Express	Body	Remote Control Door Lock Receiver																																																								
G	2016	Express	Body	Parking Assist Control Module																																																								
G	2016	Express	Body	Theft Deterrent Module																																																								
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V									V							V	V	V	V
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																												V																											
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																						
G	2016	Savana	Chassis	Electronic Brake Control Module																																																						
G	2016	Savana	Body	Body Control Module																																																						
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
G	2016	Savana	Body	Instrument Cluster																																																						
G	2016	Savana	Body	Chime Alarm Control Module																																																						
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																						
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																						
G	2016	Savana	Body	Auxiliary Heater Control Module																																																						
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																						
G	2016	Savana	Body	Parking Assist Control Module																																																						
G	2016	Savana	Body	Theft Deterrent Module																																																						
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																						
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																						
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																						
H	2004	Express/Savana	Chassis	VSES																																																						
H	2004	Express/Savana	Body	Body Control Module																																																						
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																						
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																						
H	2004	Express/Savana	Body	OnStar																																																						
H	2004	Express/Savana	Body	Base Radio																																																						
H	2004	Express/Savana	Body	Uplevel Radio																																																						
H	2004	Express/Savana	Body	Remote Function Actuation																																																						
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																						
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																						
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																						
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																						
H	2004	Express Access/Savana Pro	Chassis	VSES																																																						
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																						
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																						
H	2004	Express Access/Savana Pro	Body	OnStar																																																						
H	2004	Express Access/Savana Pro	Body	Base Radio																																																						
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																						
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																						
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																						
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																						
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																						
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																						
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																						
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																						
H	2005	Express/Savana	Chassis	VSES																																																						
H	2005	Express/Savana	Body	Body Control Module																																																						
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																						
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																						
H	2005	Express/Savana	Body	Base Radio																																																						
H	2005	Express/Savana	Body	Uplevel Radio																																																						
H	2005	Express/Savana	Body	Remote Function Actuation																																																						
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																						

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
H	2005	Express Access/Savana Pro	Chassis	VSES																																																									
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2005	Express Access/Savana Pro	Body	Base Radio																																																									
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2006	Express/Savana	Chassis	VSES																																																									
H	2006	Express/Savana	Body	Body Control Module																																																									
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2006	Express/Savana	Body	Passenger Presence System																																																									
H	2006	Express/Savana	Body	Base Radio																																																									
H	2006	Express/Savana	Body	Uplevel Radio																																																									
H	2006	Express/Savana	Body	Remote Function Actuation																																																									
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
H	2006	Express Access/Savana Pro	Chassis	VSES																																																									
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2006	Express Access/Savana Pro	Body	Base Radio																																																									
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express/Savana	Body	Body Control Module																																																										
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2007	Express/Savana	Body	Passenger Presence System																																																										
H	2007	Express/Savana	Body	Base Radio																																																										
H	2007	Express/Savana	Body	Uplevel Radio																																																										
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2007	Express Access/Savana Pro	Body	Base Radio																																																										
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express/Savana	Body	Body Control Module																																																										
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2008	Express/Savana	Body	Passenger Presence System																																																										
H	2008	Express/Savana	Body	Radio																																																									
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express/Savana	Body	Rollover Sensor																																																										
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express/Savana	Body	Theft Deterrent Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module																																																										
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																																										
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express/Savana	Body	Theft Deterrent Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express/Savana	Body	Body Control Module																																																										
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2010	Express/Savana	Body	Passenger Presence System																																																										
H	2010	Express/Savana	Body	Radio																																																									
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express/Savana	Body	Rollover Sensor																																																										
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express/Savana	Body	Theft Deterrent Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2010	Express Access/Savana Pro	Body	Radio																																																										
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2011	Express/Savana	Body	Body Control Module																																																										
H	2011	Express/Savana	Body	Digital Radio Receiver																																																										
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2011	Express/Savana	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2011	Express/Savana	Body	Radio																																																										
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2011	Express/Savana	Body	Rollover Sensor																																																										
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2011	Express/Savana	Body	Theft Deterrent Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2011	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2011	Express Access/Savana Pro	Body	Radio																																																										
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2012	Express/Savana	Body	Body Control Module																																																										
H	2012	Express/Savana	Body	Digital Radio Receiver																																																										
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2012	Express/Savana	Body	Passenger Presence System																																																										
H	2012	Express/Savana	Body	Radio																																																										
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2012	Express/Savana	Body	Rollover Sensor																																																										
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2012	Express/Savana	Body	Theft Deterrent Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2012	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2012	Express Access/Savana Pro	Body	Radio																																																								
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2013	Express/Savana	Body	Body Control Module																																																								
H	2013	Express/Savana	Body	Digital Radio Receiver																																																								
H	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2013	Express/Savana	Body	Navigation Radio																																																								
H	2013	Express/Savana	Body	Park Assist Module																																																								
H	2013	Express/Savana	Body	Passenger Presence System																																																								
H	2013	Express/Savana	Body	Radio																																																								
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2013	Express/Savana	Body	Rollover Sensor																																																								
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2013	Express/Savana	Body	Theft Deterrent Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2013	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2013	Express Access/Savana Pro	Body	Navigation Radio																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																																									
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2013	Express Access/Savana Pro	Body	Radio																																																									
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																									
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																									
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																									
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																									
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																									
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																									
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																									
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V								V							V	V	V	V
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																											V																													
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2014	Express	Chassis	Electronic Brake Control Module																																																									
H	2014	Express	Body	Body Control Module																																																								
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2014	Express	Body	Passenger Presence Module																																																								
H	2014	Express	Body	Rollover Sensor Module																																																								
H	2014	Express	Body	Instrument Cluster																																																								
H	2014	Express	Body	Chime Alarm Control Module																																																								
H	2014	Express	Body	Base Radio																																																								
H	2014	Express	Body	Navigation Radio																																																								
H	2014	Express	Body	Uplevel Radio																																																								
H	2014	Express	Body	Digital Radio Receiver Control Module																																																								
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																								
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																								
H	2014	Express	Body	Auxiliary Heater Control Module																																																								
H	2014	Express	Body	Remote Control Door Lock Receiver																																																								
H	2014	Express	Body	Parking Assist Control Module																																																								
H	2014	Express	Body	Theft Deterrent Module																																																								
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																								
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																								
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																								
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																								
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																								
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																								
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																								
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V								V							V	V	V	V
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																											V																													

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2014	Savana	Chassis	Electronic Brake Control Module																																																										
H	2014	Savana	Body	Body Control Module																																																									
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Savana	Body	Passenger Presence Module																																																										
H	2014	Savana	Body	Rollover Sensor Module																																																										
H	2014	Savana	Body	Instrument Cluster																																																										
H	2014	Savana	Body	Chime Alarm Control Module																																																										
H	2014	Savana	Body	Base Radio																																																										
H	2014	Savana	Body	Navigation Radio																																																										
H	2014	Savana	Body	Uplevel Radio																																																										
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2014	Savana	Body	Auxiliary Heater Control Module																																																										
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2014	Savana	Body	Parking Assist Control Module																																																										
H	2014	Savana	Body	Theft Deterrent Module																																																										
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																	V		V								V							V	V	V	V
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																											V																														
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2015	Express	Chassis	Electronic Brake Control Module																																																										
H	2015	Express	Body	Body Control Module																																																										
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Express	Body	Rollover Sensor Module																																																										
H	2015	Express	Body	Instrument Cluster																																																										
H	2015	Express	Body	Digital Radio Receiver Control Module																																																										
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2015	Express	Body	Auxiliary Heater Control Module																																																										
H	2015	Express	Body	Remote Control Door Lock Receiver																																																										
H	2015	Express	Body	Parking Assist Control Module																																																										
H	2015	Express	Body	Theft Deterrent Module																																																										
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																	V		V								V							V	V	V	V
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																											V																														
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2015	Savana	Chassis	Electronic Brake Control Module																																																										
H	2015	Savana	Body	Body Control Module																																																										
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2015	Savana	Body	Rollover Sensor Module																																																							
H	2015	Savana	Body	Instrument Cluster																																																							
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																							
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																							
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																							
H	2015	Savana	Body	Auxiliary Heater Control Module																																																							
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																							
H	2015	Savana	Body	Parking Assist Control Module																																																							
H	2015	Savana	Body	Theft Deterrent Module																																																							
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																							
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																							
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																							
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																							
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																							
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																							
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V								V						V	V	V	V
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																												V																											
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																							
H	2016	Express	Chassis	Electronic Brake Control Module																																																							
H	2016	Express	Body	Body Control Module																																																							
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
H	2016	Express	Body	Instrument Cluster																																																							
H	2016	Express	Body	Chime Alarm Control Module																																																							
H	2016	Express	Body	Base Radio																																																							
H	2016	Express	Body	Navigation Radio																																																							
H	2016	Express	Body	Uplevel Radio																																																							
H	2016	Express	Body	Digital Radio Receiver Control Module																																																							
H	2016	Express	Body	Telematics Communication Interface Control Module																																																							
H	2016	Express	Body	Auxiliary Heater Control Module																																																							
H	2016	Express	Body	Remote Control Door Lock Receiver																																																							
H	2016	Express	Body	Parking Assist Control Module																																																							
H	2016	Express	Body	Theft Deterrent Module																																																							
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																							
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																							
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																							
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																							
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																							
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																							
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V								V						V	V	V	V
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																												V																											
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																							
H	2016	Savana	Chassis	Electronic Brake Control Module																																																							
H	2016	Savana	Body	Body Control Module																																																							
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
H	2016	Savana	Body	Instrument Cluster																																																							
H	2016	Savana	Body	Chime Alarm Control Module																																																							
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																							
H	2016	Savana	Body	Telematics Communication Interface Control Module																																																							
H	2016	Savana	Body	Auxiliary Heater Control Module																																																							
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																							
H	2016	Savana	Body	Parking Assist Control Module																																																							

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2016	Savana	Body	Theft Deterrent Module																																																								
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																								
J	2004	ALL	Chassis	Electronic Brake Control Module																																																								
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
J	2007	ALL	Chassis	Electronic Brake Control Module																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V			V	V																												
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V			V	V																												
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer												V													V	V																														
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer												V													V	V																														
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer												V													V	V																														
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer												V													V																															
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																								
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																								
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																																								
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																								
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Tracker	Chassis	Power Steering Control Module																																																								
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2013	Tracker	Body	Body Control Module																																																								
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2013	Tracker	Body	Passenger Presence Module																																																								
J	2013	Tracker	Body	Instrument Cluster																																																								
J	2013	Tracker	Body	Radio																																																								
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																																								
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																																								
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																																								
J	2013	Tracker	Body	Front Seat Heating Control Module																																																								
J	2013	Tracker	Body	Parking Assist Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2013	Tracker	Body	Frontview Camera Module																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																										
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V			V	V																														
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V			V	V																														
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer												V													V	V																																
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer												V													V	V																																
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer												V													V																																
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer												V													V	V																																
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2013	Trax	Chassis	Electronic Brake Control Module																																																										
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Trax	Chassis	Power Steering Control Module																																																										
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Trax	Body	Body Control Module																																																										
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Trax	Body	Passenger Presence Module																																																										
J	2013	Trax	Body	Instrument Cluster																																																										
J	2013	Trax	Body	Radio																																																										
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																										
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Trax	Body	Front Seat Heating Control Module																																																										
J	2013	Trax	Body	Parking Assist Control Module																																																										
J	2013	Trax	Body	Frontview Camera Module																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission											V												V	V	V																																	
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission											V												V	V	V																																	
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																										
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V			V	V																														
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V			V	V																														
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer												V													V	V																																
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer												V													V	V																																
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer												V													V	V																																
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer												V													V																																
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																										
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																										
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2014	Tracker	Chassis	Power Steering Control Module																																																										
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Tracker	Body	Body Control Module																																																										
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Tracker	Body	Passenger Presence Module																																																										
J	2014	Tracker	Body	Instrument Cluster																																																										
J	2014	Tracker	Body	Radio																																																									
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																																										
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Tracker	Body	Front Seat Heating Control Module																																																										
J	2014	Tracker	Body	Parking Assist Control Module																																																										
J	2014	Tracker	Body	Frontview Camera Module																																																										
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																											
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V			V	V																															
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V			V	V																															
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																											
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer												V													V	V																																	
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer												V													V	V																																	
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																												
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																											
J	2014	Trax	Chassis	Electronic Brake Control Module																																																											
J	2014	Trax	Chassis	Power Steering Control Module																																																											
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2014	Trax	Body	Body Control Module																																																											
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2014	Trax	Body	Passenger Presence Module																																																											
J	2014	Trax	Body	Instrument Cluster																																																											
J	2014	Trax	Body	Radio																																																											
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																											
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																											
J	2014	Trax	Body	Front Seat Heating Control Module																																																											
J	2014	Trax	Body	Parking Assist Control Module																																																											
J	2014	Trax	Body	Frontview Camera Module																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																											
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																											
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																								V			V	V																															
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																								V			V	V																															
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																											
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer												V													V	V																																	
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer												V													V	V																																	
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer												V													V	V																														
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer												V													V																															
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																								
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																								
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																																								
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																								
J	2015	Tracker	Chassis	Power Steering Control Module																																																								
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2015	Tracker	Body	Body Control Module																																																								
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Tracker	Body	Instrument Cluster																																																								
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																																								
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																																								
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																																								
J	2015	Tracker	Body	Front Seat Heating Control Module																																																								
J	2015	Tracker	Body	Parking Assist Control Module																																																								
J	2015	Tracker	Body	Frontview Camera Module																																																								
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																								
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																							V			V	V																													
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																							V			V	V																													
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																								
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission												V													V	V																															
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission												V													V	V																															
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																								
J	2015	Trax	Powertrain	Chassis Control Module																																																								
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																								
J	2015	Trax	Chassis	Electronic Brake Control Module																																																								
J	2015	Trax	Chassis	Power Steering Control Module																																																								
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2015	Trax	Body	Body Control Module																																																								
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Trax	Body	Passenger Presence Module																																																								
J	2015	Trax	Body	Instrument Cluster																																																								
J	2015	Trax	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Trax	Body	Seat Memory Control Module																																																										
J	2015	Trax	Body	Front Seat Heating Control Module																																																										
J	2015	Trax	Body	Right Side Object Detection Control Module																																																										
J	2015	Trax	Body	Left Side Object Detection Control Module																																																										
J	2015	Trax	Body	Parking Assist Control Module																																																										
J	2015	Trax	Body	Frontview Camera Module																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer												V												V	V																																	
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer												V												V	V																																	
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																										
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2016	Tracker	Chassis	Power Steering Control Module																																																										
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Tracker	Body	Body Control Module																																																										
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Tracker	Body	Instrument Cluster																																																										
J	2016	Tracker	Body	Trailer Interface Control Module																																																										
J	2016	Tracker	Body	Radio																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Tracker	Body	Front Seat Heating Control Module																																																										
J	2016	Tracker	Body	Parking Assist Control Module																																																										
J	2016	Tracker	Body	Frontview Camera Module																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2016	Trax	Powertrain	Chassis Control Module																																																										
J	2016	Trax	Chassis	Electronic Brake Control Module																																																										
J	2016	Trax	Chassis	Power Steering Control Module																																																										
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Trax	Body	Body Control Module																																																									
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Trax	Body	Passenger Presence Module																																																										
J	2016	Trax	Body	Instrument Cluster																																																										
J	2016	Trax	Body	Trailer Interface Control Module																																																										
J	2016	Trax	Body	Radio																																																										
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Trax	Body	Seat Memory Control Module																																																										
J	2016	Trax	Body	Front Seat Heating Control Module																																																										
J	2016	Trax	Body	Right Side Object Detection Control Module																																																										
J	2016	Trax	Body	Left Side Object Detection Control Module																																																										
J	2016	Trax	Body	Parking Assist Control Module																																																										
J	2016	Trax	Body	Frontview Camera Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																									
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																									
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																									
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
K	2004	ALL	Chassis	ESC																																																								
K	2004	ALL	Chassis	Rear Wheel Steering																																																									
K	2004	ALL	Chassis	Tire Pressure Monitor																																																									
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																									
K	2004	ALL	Chassis	VSES																																																								
K	2004	ALL	Body	Amplifier (Bose)																																																									
K	2004	ALL	Body	Body Control Module																																																									
K	2004	ALL	Body	CD Changer																																																									
K	2004	ALL	Body	Chime																																																									
K	2004	ALL	Body	Driver Door Module																																																									
K	2004	ALL	Body	Driver Seat Module																																																									
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																									
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2004	ALL	Body	Instrument Panel Cluster																																																									
K	2004	ALL	Body	OnStar																																																									
K	2004	ALL	Body	Passenger Door Module																																																									
K	2004	ALL	Body	Passenger Presence System																																																									
K	2004	ALL	Body	Radio Base																																																									
K	2004	ALL	Body	Radio Uplevel																																																									
K	2004	ALL	Body	Radio Navigation																																																									
K	2004	ALL	Body	Rear Aux. Climate Module																																																									
K	2004	ALL	Body	Rear HVAC																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2004	ALL	Body	Rear Seat Audio																																																									
K	2004	ALL	Body	Rear Seat Entertainment																																																									
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2004	ALL	Body	Vehicle Theft Deterrent																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																						V			
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																											
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
K	2005	ALL	Chassis	ESC																																																											
K	2005	ALL	Chassis	Rear Wheel Steering																																																											
K	2005	ALL	Chassis	Tire Pressure Monitor																																																											
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																											
K	2005	ALL	Chassis	VSES																																																											
K	2005	ALL	Body	Amplifier (Bose)																																																											
K	2005	ALL	Body	Body Control Module																																																											
K	2005	ALL	Body	CD Changer																																																											
K	2005	ALL	Body	Chime																																																											
K	2005	ALL	Body	Disc Player and Video Display																																																											
K	2005	ALL	Body	Driver Door Module																																																											
K	2005	ALL	Body	Driver Seat Module																																																											
K	2005	ALL	Body	Generator Battery Control Module																																																											
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																											
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2005	ALL	Body	Instrument Panel Cluster																																																											
K	2005	ALL	Body	Passenger Door Module																																																											
K	2005	ALL	Body	Passenger Presence System																																																											
K	2005	ALL	Body	Base Radio																																																											
K	2005	ALL	Body	Uplevel Radio																																																											
K	2005	ALL	Body	Navigation Radio																																																											
K	2005	ALL	Body	Rear Aux. Climate Module																																																											
K	2005	ALL	Body	Rear HVAC																																																											
K	2005	ALL	Body	Rear Seat Audio																																																											
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																											
K	2005	ALL	Body	Vehicle Theft Deterrent																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																							V			
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																						V			
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																									
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
K	2006	ALL	Chassis	ESC																																																								
K	2006	ALL	Chassis	Tire Pressure Monitor																																																									
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																									
K	2006	ALL	Chassis	VSES																																																								
K	2006	ALL	Body	Amplifier (Bose)																																																								
K	2006	ALL	Body	Body Control Module																																																								
K	2006	ALL	Body	CD Changer																																																								
K	2006	ALL	Body	Chime																																																								
K	2006	ALL	Body	Disc Player and Video Display																																																								
K	2006	ALL	Body	Driver Door Module																																																								
K	2006	ALL	Body	Driver Seat Module																																																								
K	2006	ALL	Body	Generator Battery Control Module																																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2006	ALL	Body	Instrument Panel Cluster																																																										
K	2006	ALL	Body	Passenger Door Module																																																										
K	2006	ALL	Body	Passenger Presence System																																																										
K	2006	ALL	Body	Base Radio																																																										
K	2006	ALL	Body	Uplevel Radio																																																										
K	2006	ALL	Body	Navigation Radio																																																										
K	2006	ALL	Body	Rear Aux. Climate Module																																																										
K	2006	ALL	Body	Rear HVAC																																																										
K	2006	ALL	Body	Rear Seat Audio																																																										
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2006	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																																										
K	2007	Avalanche	Body	Amplifier (Bose)																																																										
K	2007	Avalanche	Body	Assist Step Controller																																																										
K	2007	Avalanche	Body	Body Control Module																																																										
K	2007	Avalanche	Body	Body Control Module (aux.)																																																										
K	2007	Avalanche	Body	Digital Radio Receiver																																																										
K	2007	Avalanche	Body	Driver Door Switch																																																										
K	2007	Avalanche	Body	HVAC Control Module Auto																																																										
K	2007	Avalanche	Body	HVAC Control Module Manual																																																										
K	2007	Avalanche	Body	Instrument Panel Cluster																																																										
K	2007	Avalanche	Body	Memory Seat Module																																																										
K	2007	Avalanche	Body	Park Assist Module																																																										
K	2007	Avalanche	Body	Passenger Door Switch																																																										
K	2007	Avalanche	Body	Passenger Presence System																																																										
K	2007	Avalanche	Body	Radio																																																										
K	2007	Avalanche	Body	Rear Heated Seat Module																																																										
K	2007	Avalanche	Body	Rear HVAC/RSA																																																										
K	2007	Avalanche	Body	Rollover Sensor																																																										
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2007	Avalanche	Body	Theft Deterrent Module																																																										
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Suburban	Chassis	Electronic Suspension Control																																																										
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																										
K	2007	Suburban	Body	Amplifier (Bose)																																																										
K	2007	Suburban	Body	Assist Step Controller																																																										
K	2007	Suburban	Body	Body Control Module																																																										
K	2007	Suburban	Body	Body Control Module (aux.)																																																										
K	2007	Suburban	Body	Digital Radio Receiver																																																										
K	2007	Suburban	Body	Driver Door Switch																																																										
K	2007	Suburban	Body	HVAC Control Module Auto																																																										
K	2007	Suburban	Body	HVAC Control Module Manual																																																										
K	2007	Suburban	Body	Instrument Panel Cluster																																																										
K	2007	Suburban	Body	Lift Gate Module																																																										
K	2007	Suburban	Body	Memory Seat Module																																																										
K	2007	Suburban	Body	Park Assist Module																																																										
K	2007	Suburban	Body	Passenger Door Switch																																																										
K	2007	Suburban	Body	Passenger Presence System																																																										
K	2007	Suburban	Body	Radio																																																										
K	2007	Suburban	Body	Rear Heated Seat Module																																																										
K	2007	Suburban	Body	Rear HVAC/RSA																																																										
K	2007	Suburban	Body	Rollover Sensor																																																										
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2007	Suburban	Body	Theft Deterrent Module																																																										
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V										V			V						
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																														
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Silverado	Chassis	Electronic Suspension Control																																																										
K	2007	Silverado	Chassis	Trailer Brake Control Module																																																										
K	2007	Silverado	Body	Amplifier (Bose)																																																										
K	2007	Silverado	Body	Body Control Module																																																										
K	2007	Silverado	Body	Body Control Module (aux.)																																																										
K	2007	Silverado	Body	Digital Radio Receiver																																																										
K	2007	Silverado	Body	Driver Door Switch																																																										
K	2007	Silverado	Body	HVAC Control Module Auto																																																										
K	2007	Silverado	Body	HVAC Control Module Manual																																																										
K	2007	Silverado	Body	Instrument Panel Cluster																																																										
K	2007	Silverado	Body	Memory Seat Module																																																										
K	2007	Silverado	Body	Park Assist Module																																																										
K	2007	Silverado	Body	Passenger Door Switch																																																										
K	2007	Silverado	Body	Passenger Presence System																																																										
K	2007	Silverado	Body	Radio																																																										
K	2007	Silverado	Body	Rear Heated Seat Module																																																										
K	2007	Silverado	Body	Rear HVAC/RSA																																																										
K	2007	Silverado	Body	Rollover Sensor																																																										
K	2007	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2007	Silverado	Body	Theft Deterrent Module																																																										
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																											
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																											
K	2007	Tahoe	Body	Amplifier (Bose)																																																											
K	2007	Tahoe	Body	Assist Step Controller																																																											
K	2007	Tahoe	Body	Body Control Module																																																											
K	2007	Tahoe	Body	Body Control Module (aux.)																																																											
K	2007	Tahoe	Body	Digital Radio Receiver																																																											
K	2007	Tahoe	Body	Driver Door Switch																																																											
K	2007	Tahoe	Body	HVAC Control Module Auto																																																											
K	2007	Tahoe	Body	HVAC Control Module Manual																																																											
K	2007	Tahoe	Body	Instrument Panel Cluster																																																											
K	2007	Tahoe	Body	Lift Gate Module																																																											
K	2007	Tahoe	Body	Memory Seat Module																																																											
K	2007	Tahoe	Body	Park Assist Module																																																											
K	2007	Tahoe	Body	Passenger Door Switch																																																											
K	2007	Tahoe	Body	Passenger Presence System																																																											
K	2007	Tahoe	Body	Radio																																																										
K	2007	Tahoe	Body	Rear Heated Seat Module																																																											
K	2007	Tahoe	Body	Rear HVAC/RSA																																																											
K	2007	Tahoe	Body	Rollover Sensor																																																											
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																											
K	2007	Tahoe	Body	Theft Deterrent Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2008	Avalanche	Chassis	Electronic Brake Control Module																																																											
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																											
K	2008	Avalanche	Body	Amplifier (Bose)																																																											
K	2008	Avalanche	Body	Assist Step Controller																																																											
K	2008	Avalanche	Body	Body Control Module																																																											
K	2008	Avalanche	Body	Body Control Module (aux.)																																																											
K	2008	Avalanche	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2008	Avalanche	Body	Driver Door Switch																																																										
K	2008	Avalanche	Body	HVAC Control Module Auto																																																										
K	2008	Avalanche	Body	HVAC Control Module Manual																																																										
K	2008	Avalanche	Body	Instrument Panel Cluster																																																										
K	2008	Avalanche	Body	Memory Seat Module																																																										
K	2008	Avalanche	Body	Park Assist Module																																																										
K	2008	Avalanche	Body	Passenger Door Switch																																																										
K	2008	Avalanche	Body	Passenger Presence System																																																										
K	2008	Avalanche	Body	Radio																																																										
K	2008	Avalanche	Body	Rear Heated Seat Module																																																										
K	2008	Avalanche	Body	Rear HVAC/RSA																																																										
K	2008	Avalanche	Body	Rollover Sensor																																																										
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2008	Avalanche	Body	Theft Deterrent Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Suburban	Chassis	Electronic Suspension Control																																																										
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																										
K	2008	Suburban	Body	Amplifier (Bose)																																																										
K	2008	Suburban	Body	Assist Step Controller																																																										
K	2008	Suburban	Body	Body Control Module																																																										
K	2008	Suburban	Body	Body Control Module (aux.)																																																										
K	2008	Suburban	Body	Digital Radio Receiver																																																										
K	2008	Suburban	Body	Driver Door Switch																																																										
K	2008	Suburban	Body	HVAC Control Module Auto																																																										
K	2008	Suburban	Body	HVAC Control Module Manual																																																										
K	2008	Suburban	Body	Instrument Panel Cluster																																																										
K	2008	Suburban	Body	Lift Gate Module																																																										
K	2008	Suburban	Body	Memory Seat Module																																																										
K	2008	Suburban	Body	Park Assist Module																																																										
K	2008	Suburban	Body	Passenger Door Switch																																																										
K	2008	Suburban	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2008	Suburban	Body	Radio																																																								
K	2008	Suburban	Body	Rear Heated Seat Module																																																								
K	2008	Suburban	Body	Rear HVAC/RSA																																																								
K	2008	Suburban	Body	Rollover Sensor																																																								
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																																								
K	2008	Suburban	Body	Theft Deterrent Module																																																								
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V										V			V			
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																													
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2008	Silverado	Chassis	Electronic Suspension Control																																																								
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																								
K	2008	Silverado	Body	Amplifier (Bose)																																																								
K	2008	Silverado	Body	Body Control Module																																																								
K	2008	Silverado	Body	Body Control Module (aux.)																																																								
K	2008	Silverado	Body	Digital Radio Receiver																																																								
K	2008	Silverado	Body	Driver Door Switch																																																								
K	2008	Silverado	Body	HVAC Control Module Auto																																																								
K	2008	Silverado	Body	HVAC Control Module Manual																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2008	Silverado	Body	Instrument Panel Cluster																																																										
K	2008	Silverado	Body	Memory Seat Module																																																										
K	2008	Silverado	Body	Park Assist Module																																																										
K	2008	Silverado	Body	Passenger Door Switch																																																										
K	2008	Silverado	Body	Passenger Presence System																																																										
K	2008	Silverado	Body	Radio																																																										
K	2008	Silverado	Body	Rear Heated Seat Module																																																										
K	2008	Silverado	Body	Rear HVAC/RSA																																																										
K	2008	Silverado	Body	Rollover Sensor																																																										
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2008	Silverado	Body	Theft Deterrent Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2008	Tahoe	Body	Amplifier (Bose)																																																										
K	2008	Tahoe	Body	Assist Step Controller																																																										
K	2008	Tahoe	Body	Body Control Module																																																										
K	2008	Tahoe	Body	Body Control Module (aux.)																																																										
K	2008	Tahoe	Body	Digital Radio Receiver																																																										
K	2008	Tahoe	Body	Driver Door Switch																																																										
K	2008	Tahoe	Body	HVAC Control Module Auto																																																										
K	2008	Tahoe	Body	HVAC Control Module Manual																																																										
K	2008	Tahoe	Body	Instrument Panel Cluster																																																										
K	2008	Tahoe	Body	Lift Gate Module																																																										
K	2008	Tahoe	Body	Memory Seat Module																																																										
K	2008	Tahoe	Body	Park Assist Module																																																										
K	2008	Tahoe	Body	Passenger Door Switch																																																										
K	2008	Tahoe	Body	Passenger Presence System																																																										
K	2008	Tahoe	Body	Radio																																																										
K	2008	Tahoe	Body	Rear Heated Seat Module																																																										
K	2008	Tahoe	Body	Rear HVAC/RSA																																																										
K	2008	Tahoe	Body	Rollover Sensor																																																										
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2008	Tahoe	Body	Theft Deterrent Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2008	Tahoe Hybrid	Body	Body Control Module																																																										
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2008	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2008	Tahoe Hybrid	Body	Memory Seat Module																																																										
K	2008	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2008	Tahoe Hybrid	Body	Radio																																																										
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																										
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																									
K	2009	Avalanche	Body	Amplifier (Bose)																																																										
K	2009	Avalanche	Body	Assist Step Controller																																																										
K	2009	Avalanche	Body	Body Control Module																																																										
K	2009	Avalanche	Body	Body Control Module (aux.)																																																										
K	2009	Avalanche	Body	Digital Radio Receiver																																																										
K	2009	Avalanche	Body	Driver Door Switch																																																										
K	2009	Avalanche	Body	HVAC Control Module Auto																																																										
K	2009	Avalanche	Body	HVAC Control Module Manual																																																										
K	2009	Avalanche	Body	Instrument Panel Cluster																																																										
K	2009	Avalanche	Body	Memory Seat Module																																																										
K	2009	Avalanche	Body	Park Assist Module																																																										
K	2009	Avalanche	Body	Passenger Door Switch																																																										
K	2009	Avalanche	Body	Passenger Presence System																																																										
K	2009	Avalanche	Body	Radio																																																										
K	2009	Avalanche	Body	Rear Heated Seat Module																																																										
K	2009	Avalanche	Body	Rear HVAC/RSA																																																										
K	2009	Avalanche	Body	Rollover Sensor																																																										
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2009	Avalanche	Body	Theft Deterrent Module																																																										
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																										
K	2009	Cheyenne	Body	Amplifier (Bose)																																																										
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2009	Cheyenne	Body	Digital Radio Receiver																																																										
K	2009	Cheyenne	Body	Driver Door Switch																																																										
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2009	Cheyenne	Body	Park Assist Module																																																										
K	2009	Cheyenne	Body	Passenger Door Switch																																																										
K	2009	Cheyenne	Body	Passenger Presence System																																																										
K	2009	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2009	Cheyenne	Body	Rollover Sensor																																																										
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2009	Cheyenne	Body	Theft Deterrent Module																																																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																											
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2009	Suburban	Chassis	Electronic Suspension Control																																																											
K	2009	Suburban	Chassis	Trailer Brake Control Module																																																											
K	2009	Suburban	Body	Amplifier (Bose)																																																											
K	2009	Suburban	Body	Assist Step Controller																																																											
K	2009	Suburban	Body	Body Control Module																																																										
K	2009	Suburban	Body	Body Control Module (aux.)																																																											
K	2009	Suburban	Body	Digital Radio Receiver																																																											
K	2009	Suburban	Body	Driver Door Switch																																																											
K	2009	Suburban	Body	HVAC Control Module Auto																																																											
K	2009	Suburban	Body	HVAC Control Module Manual																																																											
K	2009	Suburban	Body	Instrument Panel Cluster																																																											
K	2009	Suburban	Body	Left Side Object Detection Module																																																											
K	2009	Suburban	Body	Lift Gate Module																																																											
K	2009	Suburban	Body	Memory Seat Module																																																											
K	2009	Suburban	Body	Park Assist Module																																																											
K	2009	Suburban	Body	Passenger Door Switch																																																											
K	2009	Suburban	Body	Passenger Presence System																																																											
K	2009	Suburban	Body	Radio																																																											
K	2009	Suburban	Body	Rear Heated Seat Module																																																											
K	2009	Suburban	Body	Rear HVAC/RSA																																																											
K	2009	Suburban	Body	Right Side Object Detection Module																																																											
K	2009	Suburban	Body	Rollover Sensor																																																											
K	2009	Suburban	Body	Supplemental Inflatable Restraint																																																											
K	2009	Suburban	Body	Theft Deterrent Module																																																											
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V										V				V					
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																														
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2009	Silverado	Chassis	Electronic Suspension Control																																																										
K	2009	Silverado	Chassis	Trailer Brake Control Module																																																										
K	2009	Silverado	Body	Amplifier (Bose)																																																										
K	2009	Silverado	Body	Body Control Module																																																									
K	2009	Silverado	Body	Body Control Module (aux.)																																																										
K	2009	Silverado	Body	Digital Radio Receiver																																																										
K	2009	Silverado	Body	Driver Door Switch																																																										
K	2009	Silverado	Body	HVAC Control Module Auto																																																										
K	2009	Silverado	Body	HVAC Control Module Manual																																																										
K	2009	Silverado	Body	Instrument Panel Cluster																																																										
K	2009	Silverado	Body	Memory Seat Module																																																										
K	2009	Silverado	Body	Park Assist Module																																																										
K	2009	Silverado	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2009	Silverado	Body	Passenger Presence System																																																										
K	2009	Silverado	Body	Radio																																																										
K	2009	Silverado	Body	Rear Heated Seat Module																																																										
K	2009	Silverado	Body	Rear HVAC/RSA																																																										
K	2009	Silverado	Body	Rollover Sensor																																																										
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2009	Silverado	Body	Theft Deterrent Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Silverado Hybrid	Body	Body Control Module																																																										
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2009	Silverado Hybrid	Body	HVAC Control Module																																																										
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Silverado Hybrid	Body	Memory Seat Module																																																										
K	2009	Silverado Hybrid	Body	Park Assist Module																																																										
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2009	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2009	Silverado Hybrid	Body	Radio																																																										
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																										
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2009	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2009	Tahoe	Body	Amplifier (Bose)																																																										
K	2009	Tahoe	Body	Assist Step Controller																																																										
K	2009	Tahoe	Body	Body Control Module																																																										
K	2009	Tahoe	Body	Body Control Module (aux.)																																																										
K	2009	Tahoe	Body	Digital Radio Receiver																																																										
K	2009	Tahoe	Body	Driver Door Switch																																																										
K	2009	Tahoe	Body	HVAC Control Module Auto																																																										
K	2009	Tahoe	Body	HVAC Control Module Manual																																																										
K	2009	Tahoe	Body	Instrument Panel Cluster																																																										
K	2009	Tahoe	Body	Left Side Object Detection Module																																																										
K	2009	Tahoe	Body	Lift Gate Module																																																										
K	2009	Tahoe	Body	Memory Seat Module																																																										
K	2009	Tahoe	Body	Park Assist Module																																																										
K	2009	Tahoe	Body	Passenger Door Switch																																																										
K	2009	Tahoe	Body	Passenger Presence System																																																										
K	2009	Tahoe	Body	Radio																																																										
K	2009	Tahoe	Body	Rear Heated Seat Module																																																										
K	2009	Tahoe	Body	Rear HVAC/RSA																																																										
K	2009	Tahoe	Body	Right Side Object Detection Module																																																										
K	2009	Tahoe	Body	Rollover Sensor																																																										
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2009	Tahoe	Body	Theft Deterrent Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Tahoe Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																																											
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																																											
K	2009	Tahoe Hybrid	Body	HVAC Control Module																																																											
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
K	2009	Tahoe Hybrid	Body	Park Assist Module																																																											
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																																											
K	2009	Tahoe Hybrid	Body	Radio																																																											
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																											
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																											
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																											
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2010	Avalanche	Chassis	Electronic Brake Control Module																																																											
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Avalanche	Body	Amplifier (Bose)																																																											
K	2010	Avalanche	Body	Assist Step Controller																																																											
K	2010	Avalanche	Body	Body Control Module																																																											
K	2010	Avalanche	Body	Body Control Module (aux.)																																																											
K	2010	Avalanche	Body	Digital Radio Receiver																																																											
K	2010	Avalanche	Body	Driver Door Switch																																																											
K	2010	Avalanche	Body	HVAC Control Module Auto																																																											
K	2010	Avalanche	Body	HVAC Control Module Manual																																																											
K	2010	Avalanche	Body	Instrument Panel Cluster																																																											
K	2010	Avalanche	Body	Memory Seat Module																																																											
K	2010	Avalanche	Body	Park Assist Module																																																											
K	2010	Avalanche	Body	Passenger Door Switch																																																											
K	2010	Avalanche	Body	Passenger Presence System																																																											
K	2010	Avalanche	Body	Radio																																																											
K	2010	Avalanche	Body	Rear Heated Seat Module																																																											
K	2010	Avalanche	Body	Rear HVAC/RSA																																																											
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2010	Avalanche	Body	Theft Deterrent Module																																																											
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Cheyenne	Body	Amplifier (Bose)																																																										
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2010	Cheyenne	Body	Digital Radio Receiver																																																										
K	2010	Cheyenne	Body	Driver Door Switch																																																										
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2010	Cheyenne	Body	Park Assist Module																																																										
K	2010	Cheyenne	Body	Passenger Door Switch																																																										
K	2010	Cheyenne	Body	Passenger Presence System																																																										
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2010	Cheyenne	Body	Theft Deterrent Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2010	Suburban	Chassis	Electronic Suspension Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Body	Amplifier (Bose)																																																										
K	2010	Suburban	Body	Assist Step Controller																																																										
K	2010	Suburban	Body	Body Control Module																																																										
K	2010	Suburban	Body	Body Control Module (aux.)																																																										
K	2010	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2010	Suburban	Body	Driver Door Switch																																																										
K	2010	Suburban	Body	HVAC Control Module Auto																																																											
K	2010	Suburban	Body	HVAC Control Module Manual																																																											
K	2010	Suburban	Body	Instrument Panel Cluster																																																											
K	2010	Suburban	Body	Left Side Object Detection Module																																																											
K	2010	Suburban	Body	Lift Gate Module																																																											
K	2010	Suburban	Body	Memory Seat Module																																																											
K	2010	Suburban	Body	Park Assist Module																																																											
K	2010	Suburban	Body	Passenger Door Switch																																																											
K	2010	Suburban	Body	Passenger Presence System																																																											
K	2010	Suburban	Body	Radio																																																											
K	2010	Suburban	Body	Rear Heated Seat Module																																																											
K	2010	Suburban	Body	Rear HVAC/RSA																																																											
K	2010	Suburban	Body	Right Side Object Detection Module																																																											
K	2010	Suburban	Body	Supplemental Inflatable Restraint																																																											
K	2010	Suburban	Body	Theft Deterrent Module																																																											
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																											
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																											
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V											V				V			
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																															
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																											
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2010	Silverado	Chassis	Electronic Suspension Control																																																												
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2010	Silverado	Body	Amplifier (Bose)																																																												
K	2010	Silverado	Body	Body Control Module																																																												
K	2010	Silverado	Body	Body Control Module (aux.)																																																												
K	2010	Silverado	Body	Digital Radio Receiver																																																												
K	2010	Silverado	Body	Driver Door Switch																																																												
K	2010	Silverado	Body	HVAC Control Module Auto																																																												
K	2010	Silverado	Body	HVAC Control Module Manual																																																												
K	2010	Silverado	Body	Instrument Panel Cluster																																																												
K	2010	Silverado	Body	Memory Seat Module																																																												
K	2010	Silverado	Body	Park Assist Module																																																												
K	2010	Silverado	Body	Passenger Door Switch																																																												
K	2010	Silverado	Body	Passenger Presence System																																																												
K	2010	Silverado	Body	Radio																																																												
K	2010	Silverado	Body	Rear Heated Seat Module																																																												
K	2010	Silverado	Body	Rear HVAC/RSA																																																												
K	2010	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2010	Silverado	Body	Theft Deterrent Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Silverado Hybrid	Body	Body Control Module																																																												
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2010	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2010	Silverado Hybrid	Body	Heated Seat Module																																																												
K	2010	Silverado Hybrid	Body	HVAC Control Module																																																												
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2010	Silverado Hybrid	Body	Park Assist Module																																																												
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2010	Silverado Hybrid	Body	Passenger Presence System																																																												
K	2010	Silverado Hybrid	Body	Radio																																																												
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Tahoe	Body	Amplifier (Bose)																																																										
K	2010	Tahoe	Body	Assist Step Controller																																																										
K	2010	Tahoe	Body	Body Control Module																																																										
K	2010	Tahoe	Body	Body Control Module (aux.)																																																										
K	2010	Tahoe	Body	Digital Radio Receiver																																																										
K	2010	Tahoe	Body	Driver Door Switch																																																										
K	2010	Tahoe	Body	HVAC Control Module Auto																																																										
K	2010	Tahoe	Body	HVAC Control Module Manual																																																										
K	2010	Tahoe	Body	Instrument Panel Cluster																																																										
K	2010	Tahoe	Body	Left Side Object Detection Module																																																										
K	2010	Tahoe	Body	Lift Gate Module																																																										
K	2010	Tahoe	Body	Memory Seat Module																																																										
K	2010	Tahoe	Body	Park Assist Module																																																										
K	2010	Tahoe	Body	Passenger Door Switch																																																										
K	2010	Tahoe	Body	Passenger Presence System																																																										
K	2010	Tahoe	Body	Radio																																																										
K	2010	Tahoe	Body	Rear Heated Seat Module																																																										
K	2010	Tahoe	Body	Rear HVAC/RSA																																																										
K	2010	Tahoe	Body	Right Side Object Detection Module																																																										
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2010	Tahoe	Body	Theft Deterrent Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Tahoe Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																																											
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																																											
K	2010	Tahoe Hybrid	Body	HVAC Control Module																																																											
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																																											
K	2010	Tahoe Hybrid	Body	Park Assist Module																																																											
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																																											
K	2010	Tahoe Hybrid	Body	Radio																																																											
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module																																																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module																																																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2011	Avalanche	Chassis	Electronic Brake Control Module																																																											
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Avalanche	Body	Amplifier (Bose)																																																											
K	2011	Avalanche	Body	Assist Step Controller																																																											
K	2011	Avalanche	Body	Body Control Module																																																											
K	2011	Avalanche	Body	Body Control Module (aux.)																																																											
K	2011	Avalanche	Body	Digital Radio Receiver																																																											
K	2011	Avalanche	Body	Driver Door Switch																																																											
K	2011	Avalanche	Body	HVAC Control Module Auto																																																											
K	2011	Avalanche	Body	HVAC Control Module Manual																																																											
K	2011	Avalanche	Body	Instrument Panel Cluster																																																											
K	2011	Avalanche	Body	Memory Seat Module																																																											
K	2011	Avalanche	Body	Park Assist Module																																																											
K	2011	Avalanche	Body	Passenger Door Switch																																																											
K	2011	Avalanche	Body	Passenger Presence System																																																											
K	2011	Avalanche	Body	Radio																																																											
K	2011	Avalanche	Body	Rear Heated Seat Module																																																											
K	2011	Avalanche	Body	Rear HVAC/RSA																																																											
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2011	Avalanche	Body	Theft Deterrent Module																																																											
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																											
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																											
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Cheyenne	Body	Amplifier (Bose)																																																											
K	2011	Cheyenne	Body	Body Control Module																																																											
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2011	Cheyenne	Body	Digital Radio Receiver																																																											
K	2011	Cheyenne	Body	Driver Door Switch																																																											
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2011	Cheyenne	Body	Park Assist Module																																																											
K	2011	Cheyenne	Body	Passenger Door Switch																																																											
K	2011	Cheyenne	Body	Passenger Presence System																																																											
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																											
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
K	2011	Cheyenne	Body	Theft Deterrent Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																											
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2011	Suburban	Chassis	Electronic Suspension Control																																																											
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Suburban	Body	Amplifier (Bose)																																																											
K	2011	Suburban	Body	Assist Step Controller																																																											
K	2011	Suburban	Body	Body Control Module																																																											
K	2011	Suburban	Body	Body Control Module (aux.)																																																											
K	2011	Suburban	Body	Digital Radio Receiver																																																											
K	2011	Suburban	Body	Driver Door Switch																																																											
K	2011	Suburban	Body	HVAC Control Module Auto																																																											
K	2011	Suburban	Body	HVAC Control Module Manual																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2011	Suburban	Body	Instrument Panel Cluster																																																										
K	2011	Suburban	Body	Left Side Object Detection Module																																																											
K	2011	Suburban	Body	Lift Gate Module																																																											
K	2011	Suburban	Body	Memory Seat Module																																																											
K	2011	Suburban	Body	Park Assist Module																																																											
K	2011	Suburban	Body	Passenger Door Switch																																																											
K	2011	Suburban	Body	Passenger Presence System																																																											
K	2011	Suburban	Body	Radio																																																											
K	2011	Suburban	Body	Rear Heated Seat Module																																																											
K	2011	Suburban	Body	Rear HVAC/RSA																																																											
K	2011	Suburban	Body	Right Side Object Detection Module																																																											
K	2011	Suburban	Body	Supplemental Inflatable Restraint																																																											
K	2011	Suburban	Body	Theft Deterrent Module																																																											
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module																																																											
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module																																																											
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																											
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																											
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module			V	V	V	V	V	V																			V								V		V											V	V			V	V		V
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																												V																															
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V								V		V											V	V			V	V		V
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																															
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																											
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2011	Silverado	Chassis	Electronic Suspension Control																																																											
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
K	2011	Silverado	Body	Amplifier (Bose)																																																											
K	2011	Silverado	Body	Body Control Module																																																											
K	2011	Silverado	Body	Body Control Module (aux.)																																																											
K	2011	Silverado	Body	Digital Radio Receiver																																																											
K	2011	Silverado	Body	Driver Door Switch																																																											
K	2011	Silverado	Body	HVAC Control Module Auto																																																											
K	2011	Silverado	Body	HVAC Control Module Manual																																																											
K	2011	Silverado	Body	Instrument Panel Cluster																																																											
K	2011	Silverado	Body	Memory Seat Module																																																											
K	2011	Silverado	Body	Park Assist Module																																																											
K	2011	Silverado	Body	Passenger Door Switch																																																											
K	2011	Silverado	Body	Passenger Presence System																																																											
K	2011	Silverado	Body	Radio																																																											
K	2011	Silverado	Body	Rear Heated Seat Module																																																											
K	2011	Silverado	Body	Rear HVAC/RSA																																																											
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																																											
K	2011	Silverado	Body	Theft Deterrent Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																											
K	2011	Silverado Hybrid	Body	Body Control Module																																																											
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																											
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																											
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																											
K	2011	Silverado Hybrid	Body	HVAC Control Module																																																											
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
K	2011	Silverado Hybrid	Body	Park Assist Module																																																											
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																											
K	2011	Silverado Hybrid	Body	Passenger Presence System																																																											
K	2011	Silverado Hybrid	Body	Radio																																																											
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																													
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																													
K	2011	Tahoe	Chassis	Electronic Brake Control Module																																																													
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																													
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																													
K	2011	Tahoe	Body	Amplifier (Bose)																																																													
K	2011	Tahoe	Body	Assist Step Controller																																																													
K	2011	Tahoe	Body	Body Control Module																																																													
K	2011	Tahoe	Body	Body Control Module (aux.)																																																													
K	2011	Tahoe	Body	Digital Radio Receiver																																																													
K	2011	Tahoe	Body	Driver Door Switch																																																													
K	2011	Tahoe	Body	HVAC Control Module Auto																																																													
K	2011	Tahoe	Body	HVAC Control Module Manual																																																													
K	2011	Tahoe	Body	Instrument Panel Cluster																																																													
K	2011	Tahoe	Body	Left Side Object Detection Module																																																													
K	2011	Tahoe	Body	Lift Gate Module																																																													
K	2011	Tahoe	Body	Memory Seat Module																																																													
K	2011	Tahoe	Body	Park Assist Module																																																													
K	2011	Tahoe	Body	Passenger Door Switch																																																													
K	2011	Tahoe	Body	Passenger Presence System																																																													
K	2011	Tahoe	Body	Radio																																																													
K	2011	Tahoe	Body	Rear Heated Seat Module																																																													
K	2011	Tahoe	Body	Rear HVAC/RSA																																																													
K	2011	Tahoe	Body	Right Side Object Detection Module																																																													
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																													
K	2011	Tahoe	Body	Theft Deterrent Module																																																													
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																													
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																													
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																													
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																													
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																													
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																													
K	2011	Tahoe Hybrid	Body	Body Control Module																																																													
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																													
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																													
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																																													
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																																													
K	2011	Tahoe Hybrid	Body	HVAC Control Module																																																													

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2011	Tahoe Hybrid	Body	Radio																																																										
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2012	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Avalanche	Body	Amplifier (Bose)																																																										
K	2012	Avalanche	Body	Assist Step Controller																																																										
K	2012	Avalanche	Body	Body Control Module																																																										
K	2012	Avalanche	Body	Body Control Module (aux.)																																																										
K	2012	Avalanche	Body	Digital Radio Receiver																																																										
K	2012	Avalanche	Body	Driver Door Switch																																																										
K	2012	Avalanche	Body	HVAC Control Module Auto																																																										
K	2012	Avalanche	Body	HVAC Control Module Manual																																																										
K	2012	Avalanche	Body	Instrument Panel Cluster																																																										
K	2012	Avalanche	Body	Memory Seat Module																																																										
K	2012	Avalanche	Body	Navigation Radio																																																										
K	2012	Avalanche	Body	Park Assist Module																																																										
K	2012	Avalanche	Body	Passenger Door Switch																																																										
K	2012	Avalanche	Body	Passenger Presence System																																																										
K	2012	Avalanche	Body	Radio																																																										
K	2012	Avalanche	Body	Rear Heated Seat Module																																																										
K	2012	Avalanche	Body	Rear HVAC/RSA																																																										
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2012	Avalanche	Body	Theft Deterrent Module																																																										
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Cheyenne	Body	Amplifier (Bose)																																																										
K	2012	Cheyenne	Body	Body Control Module																																																										
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2012	Cheyenne	Body	Digital Radio Receiver																																																										
K	2012	Cheyenne	Body	Driver Door Switch																																																										
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2012	Cheyenne	Body	Park Assist Module																																																										
K	2012	Cheyenne	Body	Passenger Door Switch																																																										
K	2012	Cheyenne	Body	Passenger Presence System																																																										
K	2012	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2012	Cheyenne	Body	Theft Deterrent Module																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2012	Suburban	Chassis	Electronic Suspension Control																																																										
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Suburban	Body	Amplifier (Bose)																																																										
K	2012	Suburban	Body	Assist Step Controller																																																										
K	2012	Suburban	Body	Body Control Module																																																										
K	2012	Suburban	Body	Body Control Module (aux.)																																																										
K	2012	Suburban	Body	Digital Radio Receiver																																																										
K	2012	Suburban	Body	Driver Door Switch																																																										
K	2012	Suburban	Body	HVAC Control Module Auto																																																										
K	2012	Suburban	Body	HVAC Control Module Manual																																																										
K	2012	Suburban	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2012	Suburban	Body	Left Side Object Detection Module																																																										
K	2012	Suburban	Body	Lift Gate Module																																																											
K	2012	Suburban	Body	Memory Seat Module																																																											
K	2012	Suburban	Body	Navigation Radio																																																											
K	2012	Suburban	Body	Park Assist Module																																																											
K	2012	Suburban	Body	Passenger Door Switch																																																											
K	2012	Suburban	Body	Passenger Presence System																																																											
K	2012	Suburban	Body	Radio																																																											
K	2012	Suburban	Body	Rear Heated Seat Module																																																											
K	2012	Suburban	Body	Rear HVAC/RSA																																																											
K	2012	Suburban	Body	Right Side Object Detection Module																																																											
K	2012	Suburban	Body	Supplemental Inflatable Restraint																																																											
K	2012	Suburban	Body	Theft Deterrent Module																																																											
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																											
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																											
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																											
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V												V	V			V	V		V
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																												V																														
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																											
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V												V	V			V	V		V
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																														
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																											
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																											
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2012	Silverado	Chassis	Electronic Suspension Control																																																										
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
K	2012	Silverado	Body	Amplifier (Bose)																																																											
K	2012	Silverado	Body	Body Control Module																																																											
K	2012	Silverado	Body	Body Control Module (aux.)																																																											
K	2012	Silverado	Body	Digital Radio Receiver																																																											
K	2012	Silverado	Body	Driver Door Switch																																																											
K	2012	Silverado	Body	HVAC Control Module Auto																																																											
K	2012	Silverado	Body	HVAC Control Module Manual																																																											
K	2012	Silverado	Body	Instrument Panel Cluster																																																											
K	2012	Silverado	Body	Memory Seat Module																																																											
K	2012	Silverado	Body	Navigation Radio																																																											
K	2012	Silverado	Body	Park Assist Module																																																											
K	2012	Silverado	Body	Passenger Door Switch																																																											
K	2012	Silverado	Body	Passenger Presence System																																																											
K	2012	Silverado	Body	Radio																																																											
K	2012	Silverado	Body	Rear Heated Seat Module																																																											
K	2012	Silverado	Body	Rear HVAC/RSA																																																											
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																																											
K	2012	Silverado	Body	Theft Deterrent Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																											
K	2012	Silverado Hybrid	Body	Body Control Module																																																											
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																											
K	2012	Silverado Hybrid	Body	Driver Door Switch																																																											
K	2012	Silverado Hybrid	Body	Heated Seat Module																																																											
K	2012	Silverado Hybrid	Body	HVAC Control Module																																																											
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
K	2012	Silverado Hybrid	Body	Navigation Radio																																																											
K	2012	Silverado Hybrid	Body	Park Assist Module																																																											
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																																											
K	2012	Silverado Hybrid	Body	Passenger Presence System																																																											
K	2012	Silverado Hybrid	Body	Radio																																																											
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2012	Tahoe	Chassis	EBCM with Trailer Brake																																																										
K	2012	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Tahoe	Body	Amplifier (Bose)																																																										
K	2012	Tahoe	Body	Assist Step Controller																																																										
K	2012	Tahoe	Body	Body Control Module																																																										
K	2012	Tahoe	Body	Body Control Module (aux.)																																																										
K	2012	Tahoe	Body	Digital Radio Receiver																																																										
K	2012	Tahoe	Body	Driver Door Switch																																																										
K	2012	Tahoe	Body	HVAC Control Module Auto																																																										
K	2012	Tahoe	Body	HVAC Control Module Manual																																																										
K	2012	Tahoe	Body	Instrument Panel Cluster																																																										
K	2012	Tahoe	Body	Left Side Object Detection Module																																																										
K	2012	Tahoe	Body	Lift Gate Module																																																										
K	2012	Tahoe	Body	Memory Seat Module																																																										
K	2012	Tahoe	Body	Navigation Radio																																																										
K	2012	Tahoe	Body	Park Assist Module																																																										
K	2012	Tahoe	Body	Passenger Door Switch																																																										
K	2012	Tahoe	Body	Passenger Presence System																																																										
K	2012	Tahoe	Body	Radio																																																										
K	2012	Tahoe	Body	Rear Heated Seat Module																																																										
K	2012	Tahoe	Body	Rear HVAC/RSA																																																										
K	2012	Tahoe	Body	Right Side Object Detection Module																																																										
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2012	Tahoe	Body	Theft Deterrent Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2012	Tahoe Hybrid	Body	Body Control Module																																																										
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2012	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																										
K	2012	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2012	Tahoe Hybrid	Body	Radio																																																										
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Avalanche	Body	Amplifier (Bose)																																																										
K	2013	Avalanche	Body	Assist Step Controller																																																										
K	2013	Avalanche	Body	Body Control Module																																																										
K	2013	Avalanche	Body	Body Control Module (aux.)																																																										
K	2013	Avalanche	Body	Digital Radio Receiver																																																										
K	2013	Avalanche	Body	Driver Door Switch																																																										
K	2013	Avalanche	Body	HVAC Control Module Auto																																																										
K	2013	Avalanche	Body	HVAC Control Module Manual																																																										
K	2013	Avalanche	Body	Instrument Panel Cluster																																																										
K	2013	Avalanche	Body	Memory Seat Module																																																										
K	2013	Avalanche	Body	Navigation Radio																																																										
K	2013	Avalanche	Body	Park Assist Module																																																										
K	2013	Avalanche	Body	Passenger Door Switch																																																										
K	2013	Avalanche	Body	Passenger Presence System																																																										
K	2013	Avalanche	Body	Radio																																																										
K	2013	Avalanche	Body	Rear Heated Seat Module																																																										
K	2013	Avalanche	Body	Rear HVAC/RSA																																																										
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2013	Avalanche	Body	Theft Deterrent Module																																																										
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Cheyenne	Body	Amplifier (Bose)																																																										
K	2013	Cheyenne	Body	Body Control Module																																																										
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2013	Cheyenne	Body	Digital Radio Receiver																																																										
K	2013	Cheyenne	Body	Driver Door Switch																																																										
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2013	Cheyenne	Body	Park Assist Module																																																										
K	2013	Cheyenne	Body	Passenger Door Switch																																																										
K	2013	Cheyenne	Body	Passenger Presence System																																																										
K	2013	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2013	Cheyenne	Body	Theft Deterrent Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2013	Suburban	Chassis	Electronic Suspension Control																																																										
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Suburban	Body	Amplifier (Bose)																																																										
K	2013	Suburban	Body	Assist Step Controller																																																										
K	2013	Suburban	Body	Body Control Module																																																										
K	2013	Suburban	Body	Body Control Module (aux.)																																																										
K	2013	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2013	Suburban	Body	Driver Door Switch																																																										
K	2013	Suburban	Body	HVAC Control Module Auto																																																											
K	2013	Suburban	Body	HVAC Control Module Manual																																																											
K	2013	Suburban	Body	Instrument Panel Cluster																																																											
K	2013	Suburban	Body	Left Side Object Detection Module																																																											
K	2013	Suburban	Body	Lift Gate Module																																																											
K	2013	Suburban	Body	Memory Seat Module																																																											
K	2013	Suburban	Body	Navigation Radio																																																											
K	2013	Suburban	Body	Park Assist Module																																																											
K	2013	Suburban	Body	Passenger Door Switch																																																											
K	2013	Suburban	Body	Passenger Presence System																																																											
K	2013	Suburban	Body	Radio																																																											
K	2013	Suburban	Body	Rear Heated Seat Module																																																											
K	2013	Suburban	Body	Rear HVAC/RSA																																																											
K	2013	Suburban	Body	Right Side Object Detection Module																																																											
K	2013	Suburban	Body	Supplemental Inflatable Restraint																																																											
K	2013	Suburban	Body	Theft Deterrent Module																																																											
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																											
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																											
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																											
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V																				V							V		V												V	V		V	V		V
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																												V																														
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																											
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2013	Silverado	Chassis	Electronic Suspension Control																																																										
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2013	Silverado	Body	Amplifier (Bose)																																																										
K	2013	Silverado	Body	Body Control Module																																																										
K	2013	Silverado	Body	Body Control Module (aux.)																																																										
K	2013	Silverado	Body	Digital Radio Receiver																																																										
K	2013	Silverado	Body	Driver Door Switch																																																										
K	2013	Silverado	Body	HVAC Control Module Auto																																																										
K	2013	Silverado	Body	HVAC Control Module Manual																																																										
K	2013	Silverado	Body	Instrument Panel Cluster																																																										
K	2013	Silverado	Body	Memory Seat Module																																																										
K	2013	Silverado	Body	Navigation Radio																																																										
K	2013	Silverado	Body	Park Assist Module																																																										
K	2013	Silverado	Body	Passenger Door Switch																																																										
K	2013	Silverado	Body	Passenger Presence System																																																										
K	2013	Silverado	Body	Radio																																																										
K	2013	Silverado	Body	Rear Heated Seat Module																																																										
K	2013	Silverado	Body	Rear HVAC/RSA																																																										
K	2013	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2013	Silverado	Body	Theft Deterrent Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2013	Silverado Hybrid	Body	Body Control Module																																																										
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2013	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2013	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2013	Silverado Hybrid	Body	HVAC Control Module																																																										
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2013	Silverado Hybrid	Body	Navigation Radio																																																										
K	2013	Silverado Hybrid	Body	Park Assist Module																																																										
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2013	Silverado Hybrid	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2013	Silverado Hybrid	Body	Radio																																																										
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe	Body	Amplifier (Bose)																																																										
K	2013	Tahoe	Body	Assist Step Controller																																																										
K	2013	Tahoe	Body	Body Control Module																																																										
K	2013	Tahoe	Body	Body Control Module (aux.)																																																										
K	2013	Tahoe	Body	Digital Radio Receiver																																																										
K	2013	Tahoe	Body	Driver Door Switch																																																										
K	2013	Tahoe	Body	HVAC Control Module Auto																																																										
K	2013	Tahoe	Body	HVAC Control Module Manual																																																										
K	2013	Tahoe	Body	Instrument Panel Cluster																																																										
K	2013	Tahoe	Body	Left Side Object Detection Module																																																										
K	2013	Tahoe	Body	Lift Gate Module																																																										
K	2013	Tahoe	Body	Memory Seat Module																																																										
K	2013	Tahoe	Body	Navigation Radio																																																										
K	2013	Tahoe	Body	Park Assist Module																																																										
K	2013	Tahoe	Body	Passenger Door Switch																																																										
K	2013	Tahoe	Body	Passenger Presence System																																																										
K	2013	Tahoe	Body	Radio																																																										
K	2013	Tahoe	Body	Rear Heated Seat Module																																																										
K	2013	Tahoe	Body	Rear HVAC/RSA																																																										
K	2013	Tahoe	Body	Right Side Object Detection Module																																																										
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2013	Tahoe	Body	Theft Deterrent Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2013	Tahoe Hybrid	Body	Body Control Module																																																										
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																										
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2013	Tahoe Hybrid	Body	Radio																																																										
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																										
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																										
K	2014	Cheyenne	Chassis	Power Steering Control Module																																																										
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Cheyenne	Body	Body Control Module																																																										
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Cheyenne	Body	Passenger Presence Module																																																										
K	2014	Cheyenne	Body	Instrument Cluster																																																										
K	2014	Cheyenne	Body	Radio Control																																																										
K	2014	Cheyenne	Body	HVAC Control																																																										
K	2014	Cheyenne	Body	Radio																																																										
K	2014	Cheyenne	Body	Amplifier																																																										
K	2014	Cheyenne	Body	Media Disc Player																																																										
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																										
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2014	Cheyenne	Body	HVAC Control Module																																																								
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																								
K	2014	Cheyenne	Body	Parking Assist Control Module																																																								
K	2014	Cheyenne	Body	Frontview Camera Module																																																								
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																								
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																								
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2014	Silverado	Chassis	Electronic Brake Control Module																																																								
K	2014	Silverado	Chassis	Parking Brake Control Module																																																								
K	2014	Silverado	Chassis	Power Steering Control Module																																																								
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2014	Silverado	Body	Body Control Module																																																								
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2014	Silverado	Body	Passenger Presence Module																																																								
K	2014	Silverado	Body	Instrument Cluster																																																								
K	2014	Silverado	Body	Radio Control																																																								
K	2014	Silverado	Body	HVAC Control																																																								
K	2014	Silverado	Body	Radio																																																								
K	2014	Silverado	Body	Amplifier																																																								
K	2014	Silverado	Body	Media Disc Player																																																								
K	2014	Silverado	Body	Human Machine Interface Control Module																																																								
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																								
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																								
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																								
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																								
K	2014	Silverado	Body	Parking Assist Control Module																																																								
K	2014	Silverado	Body	Frontview Camera Module																																																								
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																								
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																		V		V								V							V	V	V	V
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																												V																												
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																								
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																								
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																								
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2014	Silverado HD	Chassis	Suspension Control Module																																																										
K	2014	Silverado HD	Body	Body Control Module																																																											
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2014	Silverado HD	Body	Passenger Presence Module																																																											
K	2014	Silverado HD	Body	Instrument Cluster																																																											
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																											
K	2014	Silverado HD	Body	Base Radio																																																											
K	2014	Silverado HD	Body	Navigation Radio																																																											
K	2014	Silverado HD	Body	Uplevel Radio																																																											
K	2014	Silverado HD	Body	Amplifier																																																											
K	2014	Silverado HD	Body	Rear Audio Control Module																																																											
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																											
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																											
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																											
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																											
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																											
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																											
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																											
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																											
K	2014	Silverado HD	Body	Seat Memory Control Module																																																											
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																											
K	2014	Silverado HD	Body	Parking Assist Control Module																																																											
K	2014	Silverado HD	Body	Theft Deterrent Module																																																											
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																											
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																											
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																											
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																											
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																											
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																											
K	2014	Suburban	Chassis	Parking Brake Control Module																																																											
K	2014	Suburban	Chassis	Suspension Control Module																																																											
K	2014	Suburban	Body	Body Control Module																																																											
K	2014	Suburban	Body	Auxiliary Body Control Module																																																											
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2014	Suburban	Body	Passenger Presence Module																																																											
K	2014	Suburban	Body	Instrument Cluster																																																											
K	2014	Suburban	Body	Base Radio																																																											
K	2014	Suburban	Body	Navigation Radio																																																											
K	2014	Suburban	Body	Uplevel Radio																																																											
K	2014	Suburban	Body	Amplifier																																																											
K	2014	Suburban	Body	Rear Audio Control Module																																																											
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																											
K	2014	Suburban	Body	Personal Audio Link Control Module																																																											
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																											
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Suburban	Body	Liftgate Control Module																																																										
K	2014	Suburban	Body	Seat Memory Control Module																																																										
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																										
K	2014	Suburban	Body	Assist Step Control Module																																																										
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																										
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																										
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																										
K	2014	Suburban	Body	Parking Assist Control Module																																																										
K	2014	Suburban	Body	Theft Deterrent Module																																																										
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																										
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																										
K	2014	Tahoe	Chassis	Suspension Control Module																																																										
K	2014	Tahoe	Body	Body Control Module																																																										
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																										
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Tahoe	Body	Passenger Presence Module																																																										
K	2014	Tahoe	Body	Instrument Cluster																																																										
K	2014	Tahoe	Body	Base Radio																																																										
K	2014	Tahoe	Body	Navigation Radio																																																										
K	2014	Tahoe	Body	Uplevel Radio																																																										
K	2014	Tahoe	Body	Amplifier																																																										
K	2014	Tahoe	Body	Rear Audio Control Module																																																										
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																										
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																										
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Tahoe	Body	Liftgate Control Module																																																										
K	2014	Tahoe	Body	Seat Memory Control Module																																																										
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																										
K	2014	Tahoe	Body	Assist Step Control Module																																																										
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																										
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																										
K	2014	Tahoe	Body	Parking Assist Control Module																																																										
K	2014	Tahoe	Body	Theft Deterrent Module																																																										
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																										
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																										
K	2015	Cheyenne	Chassis	Power Steering Control Module																																																										
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Cheyenne	Chassis	Suspension Control Module																																																										
K	2015	Cheyenne	Body	Body Control Module																				V																							V														
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Cheyenne	Body	Passenger Presence Module																																																										
K	2015	Cheyenne	Body	Instrument Cluster																																																										
K	2015	Cheyenne	Body	Radio Controls																																																										
K	2015	Cheyenne	Body	HVAC Controls																																																										
K	2015	Cheyenne	Body	Radio																																																										
K	2015	Cheyenne	Body	Amplifier																																																										
K	2015	Cheyenne	Body	Media Disc Player																																																										
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																										
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
K	2015	Cheyenne	Body	HVAC Control Module																																																										
K	2015	Cheyenne	Body	Parking Assist Control Module																																																										
K	2015	Cheyenne	Body	Frontview Camera Module																																																										
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																		V		V								V								V	V	V	V
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																											V																														
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																									
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																									
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2015	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																										
K	2015	Silverado	Chassis	Power Steering Control Module																																																										
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Silverado	Chassis	Suspension Control Module																																																										
K	2015	Silverado	Body	Body Control Module																				V																								V														
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Silverado	Body	Passenger Presence Module																																																										
K	2015	Silverado	Body	Instrument Cluster																																																										
K	2015	Silverado	Body	Radio Controls																																																										
K	2015	Silverado	Body	HVAC Controls																																																										
K	2015	Silverado	Body	Radio																																																										
K	2015	Silverado	Body	Amplifier																																																										
K	2015	Silverado	Body	Media Disc Player																																																										
K	2015	Silverado	Body	Human Machine Interface Control Module																																																										
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																																										
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2015	Silverado	Body	Parking Assist Control Module																																																										
K	2015	Silverado	Body	Frontview Camera Module																																																										
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2015	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
K	2015	Suburban	Chassis	Parking Brake Control Module																																																										
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2015	Suburban	Chassis	Power Steering Control Module																																																										
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Suburban	Chassis	Suspension Control Module																																																										
K	2015	Suburban	Body	Body Control Module																																																										
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Suburban	Body	Passenger Presence Module																																																										
K	2015	Suburban	Body	Instrument Cluster																																																										
K	2015	Suburban	Body	Radio Controls																																																										
K	2015	Suburban	Body	HVAC Controls																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2015	Suburban	Body	Radio																																																										
K	2015	Suburban	Body	Amplifier																																																										
K	2015	Suburban	Body	Media Disc Player																																																										
K	2015	Suburban	Body	Human Machine Interface Control Module																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2015	Suburban	Body	HVAC Control Module																																																											
K	2015	Suburban	Body	Liftgate Control Module																																																											
K	2015	Suburban	Body	Keyless Entry Control Module																																																											
K	2015	Suburban	Body	Assist Step Control Module																																																											
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																											
K	2015	Suburban	Body	Parking Assist Control Module																																																											
K	2015	Suburban	Body	Frontview Camera Module																																																											
K	2015	Suburban	Body	Steering Column Lock Control Module																																																											
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																											
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																											
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																											
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																											
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																											
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																											
K	2015	Tahoe	Chassis	Power Steering Control Module																																																											
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Tahoe	Chassis	Suspension Control Module																																																											
K	2015	Tahoe	Body	Body Control Module																																																											
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Tahoe	Body	Passenger Presence Module																																																											
K	2015	Tahoe	Body	Instrument Cluster																																																											
K	2015	Tahoe	Body	Radio Controls																																																											
K	2015	Tahoe	Body	HVAC Controls																																																											
K	2015	Tahoe	Body	Radio																																																										
K	2015	Tahoe	Body	Amplifier																																																										
K	2015	Tahoe	Body	Media Disc Player																																																											
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2015	Tahoe	Body	HVAC Control Module																																																											
K	2015	Tahoe	Body	Liftgate Control Module																																																											
K	2015	Tahoe	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2015	Tahoe	Body	Assist Step Control Module																																																									
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																									
K	2015	Tahoe	Body	Parking Assist Control Module																																																									
K	2015	Tahoe	Body	Frontview Camera Module																																																									
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																									
K	2015	Tahoe	Body	Battery Energy Control Module																																																									
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																									
K	2016	Cheyenne	Chassis	Power Steering Control Module																																																									
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2016	Cheyenne	Chassis	Suspension Control Module																																																									
K	2016	Cheyenne	Body	Body Control Module																																																									
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2016	Cheyenne	Body	Passenger Presence Module																																																									
K	2016	Cheyenne	Body	Instrument Cluster																																																									
K	2016	Cheyenne	Body	Radio Controls																																																									
K	2016	Cheyenne	Body	HVAC Controls																																																									
K	2016	Cheyenne	Body	Radio																																																									
K	2016	Cheyenne	Body	Amplifier																																																									
K	2016	Cheyenne	Body	Media Disc Player																																																									
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																									
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																									
K	2016	Cheyenne	Body	HVAC Control Module																																																									
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																									
K	2016	Cheyenne	Body	Parking Assist Control Module																																																									
K	2016	Cheyenne	Body	Frontview Camera Module																																																									
K	2016	Cheyenne	Body	Frontview Camera Module																																																									
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																									
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																		V		V								V							V	V	V	V
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																											V																													
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																								
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																								
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2016	Silverado	Chassis	Electronic Brake Control Module																																																								
K	2016	Silverado	Chassis	Power Steering Control Module																																																								
K	2016	Silverado	Chassis	Power Steering Control Module																																																								
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2016	Silverado	Chassis	Suspension Control Module																																																								
K	2016	Silverado	Body	Body Control Module																																																								
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2016	Silverado	Body	Passenger Presence Module																																																								
K	2016	Silverado	Body	Instrument Cluster																																																								
K	2016	Silverado	Body	Radio Controls																																																								
K	2016	Silverado	Body	HVAC Controls																																																								
K	2016	Silverado	Body	Radio (IO3)																																																								
K	2016	Silverado	Body	Radio (IOB)																																																								
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																								
K	2016	Silverado	Body	Amplifier																																																								
K	2016	Silverado	Body	Media Disc Player																																																								
K	2016	Silverado	Body	Human Machine Interface Control Module																																																								
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																								
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																								
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																								
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																								
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																								
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																								
K	2016	Silverado	Body	Parking Assist Control Module																																																								
K	2016	Silverado	Body	Frontview Camera Module																																																								
K	2016	Silverado	Body	Frontview Camera Module																																																								
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2016	Suburban	Chassis	Electronic Brake Control Module																																																								
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																								
K	2016	Suburban	Chassis	Parking Brake Control Module																																																								
K	2016	Suburban	Chassis	Power Steering Control Module																																																								
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2016	Suburban	Chassis	Suspension Control Module																																																								
K	2016	Suburban	Body	Body Control Module																																																								
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2016	Suburban	Body	Passenger Presence Module																																																										
K	2016	Suburban	Body	Instrument Cluster																																																										
K	2016	Suburban	Body	Radio Controls																																																										
K	2016	Suburban	Body	HVAC Controls																																																										
K	2016	Suburban	Body	Radio																																																										
K	2016	Suburban	Body	Amplifier																																																										
K	2016	Suburban	Body	Media Disc Player																																																										
K	2016	Suburban	Body	Human Machine Interface Control Module																																																											
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																																											
K	2016	Suburban	Body	HVAC Control Module																																																											
K	2016	Suburban	Body	Liftgate Control Module																																																											
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																											
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																											
K	2016	Suburban	Body	Keyless Entry Control Module																																																											
K	2016	Suburban	Body	Assist Step Control Module																																																											
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																											
K	2016	Suburban	Body	Parking Assist Control Module																																																											
K	2016	Suburban	Body	Frontview Camera Module																																																											
K	2016	Suburban	Body	Steering Column Lock Control Module																																																											
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																											
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																											
K	2016	Tahoe	Chassis	Power Steering Control Module																																																											
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2016	Tahoe	Chassis	Suspension Control Module																																																											
K	2016	Tahoe	Body	Body Control Module																																																											
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2016	Tahoe	Body	Passenger Presence Module																																																											
K	2016	Tahoe	Body	Instrument Cluster																																																											
K	2016	Tahoe	Body	Radio Controls																																																											
K	2016	Tahoe	Body	HVAC Controls																																																											
K	2016	Tahoe	Body	Radio																																																											
K	2016	Tahoe	Body	Amplifier																																																										
K	2016	Tahoe	Body	Media Disc Player																																																											
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																											
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																											
K	2016	Tahoe	Body	HVAC Control Module																																																											
K	2016	Tahoe	Body	Liftgate Control Module																																																											
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																											
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																											
K	2016	Tahoe	Body	Keyless Entry Control Module																																																											
K	2016	Tahoe	Body	Assist Step Control Module																																																											
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																											
K	2016	Tahoe	Body	Parking Assist Control Module																																																											
K	2016	Tahoe	Body	Frontview Camera Module																																																											
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																											
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2004	ALL	Chassis	4WAL 3 Sensor																																																										
L	2004	ALL	Body	Body Control Module																																																										
L	2004	ALL	Body	Instrument Panel Cluster																																																										
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2005	Astro	Chassis	4WAL 3 Sensor																																																										
L	2005	Astro	Body	Body Control Module																																																										
L	2005	Astro	Body	Instrument Panel Cluster																																																										
L	2005	Astro	Body	Supplemental Inflatable Restraint																																																										
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																																										
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																																										
L	2005	Equinox	Chassis	Electric Power Steering																																																										
L	2005	Equinox	Body	Body Control Module																																																										
L	2005	Equinox	Body	Instrument Panel Cluster																																																										
L	2005	Equinox	Body	Radio																																																										
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2006	ALL	Chassis	Traction Control Yes																																																										
L	2006	ALL	Chassis	Traction Control No																																																										
L	2006	ALL	Chassis	Electric Power Steering																																																										
L	2006	ALL	Body	Body Control Module																																																										
L	2006	ALL	Body	Instrument Panel Cluster																																																										
L	2006	ALL	Body	Radio																																																										
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																																										
L	2007	ALL	Chassis	Power Steering Control Module																																																										
L	2007	ALL	Body	Body Control Module																																																										
L	2007	ALL	Body	Digital Radio Receiver																																																										
L	2007	ALL	Body	Heated Seat Module																																																										
L	2007	ALL	Body	HVAC Control Module																																																										
L	2007	ALL	Body	Instrument Panel Cluster																																																										
L	2007	ALL	Body	Passenger Presence System																																																										
L	2007	ALL	Body	Radio																																																										
L	2007	ALL	Body	Rollover Sensor																																																										
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Body	Theft Deterrent Module																																																										
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																									
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2008	Captiva Sport	Body	Body Control Module																																																										
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2008	Captiva Sport	Body	HVAC Control Module Auto																																																										
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																																										
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2008	Captiva Sport	Body	Passenger Presence System																																																										
L	2008	Captiva Sport	Body	Radio																																																										
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2008	Captiva Sport	Body	Rollover Sensor																																																										
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2008	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2008	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2008	Equinox	Chassis	Power Steering Control Module																																																										
L	2008	Equinox	Body	Body Control Module																																																										
L	2008	Equinox	Body	Digital Radio Receiver																																																										
L	2008	Equinox	Body	Heated Seat Module																																																										
L	2008	Equinox	Body	HVAC Control Module																																																										
L	2008	Equinox	Body	Instrument Panel Cluster																																																										
L	2008	Equinox	Body	Passenger Presence System																																																										
L	2008	Equinox	Body	Radio																																																										
L	2008	Equinox	Body	Rollover Sensor																																																										
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2008	Equinox	Body	Theft Deterrent Module																																																										
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																										
L	2009	Captiva Sport	Body	Body Control Module																																																										
L	2009	Captiva Sport	Body	HVAC Control Module Auto																																																										
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																																										
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2009	Captiva Sport	Body	Passenger Presence System																																																										
L	2009	Captiva Sport	Body	Radio																																																										
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2009	Captiva Sport	Body	Rollover Sensor																																																										
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2009	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																									
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2009	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2009	Equinox	Chassis	Power Steering Control Module																																																										
L	2009	Equinox	Body	Body Control Module																																																										
L	2009	Equinox	Body	Digital Radio Receiver																																																										
L	2009	Equinox	Body	Heated Seat Module																																																										
L	2009	Equinox	Body	HVAC Control Module																																																										
L	2009	Equinox	Body	Instrument Panel Cluster																																																										
L	2009	Equinox	Body	Passenger Presence System																																																										
L	2009	Equinox	Body	Radio																																																										
L	2009	Equinox	Body	Rollover Sensor																																																										
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2009	Equinox	Body	Theft Deterrent Module																																																										
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																										
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																										
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																										
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																										
L	2010	Captiva Sport	Body	Body Control Module																																																										
L	2010	Captiva Sport	Body	HVAC Control Module																																																										
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2010	Captiva Sport	Body	Passenger Presence System																																																										
L	2010	Captiva Sport	Body	Radio																																																										
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2010	Captiva Sport	Body	Rollover Sensor																																																										
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2010	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																										
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																										
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																										
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2010	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2010	Equinox	Body	Body Control Module																																																										
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2010	Equinox	Body	Passenger Presence Module																																																										
L	2010	Equinox	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2010	Equinox	Body	Radio																																																									
L	2010	Equinox	Body	Multimedia Player Interface Module																																																										
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2010	Equinox	Body	Liftgate Control Module																																																										
L	2010	Equinox	Body	Parking Assist Control Module																																																										
L	2010	Equinox	Body	Frontview Camera Module																																																										
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																																										
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																	
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																	
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																										
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																										
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
L	2011	Captiva	Chassis	Electronic Brake Control Module																																																										
L	2011	Captiva	Chassis	Parking Brake Control Module																																																										
L	2011	Captiva	Body	Body Control Module																																																										
L	2011	Captiva	Body	Auxiliary Body Control Module																																																										
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2011	Captiva	Body	Instrument Cluster																																																										
L	2011	Captiva	Body	Headlamp Control Module																																																										
L	2011	Captiva	Body	HVAC Control Module																																																										
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																										
L	2011	Captiva	Body	Parking Assist Control Module																																																										
L	2011	Captiva	Body	Theft Deterrent Module																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																										
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																										
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																										
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																																										
L	2011	Captiva Sport	Body	Body Control Module																																																										
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2011	Captiva Sport	Body	HVAC Control Module																																																										
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2011	Captiva Sport	Body	Passenger Presence System																																																										
L	2011	Captiva Sport	Body	Radio																																																										
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2011	Captiva Sport	Body	Rollover Sensor																																																										
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2011	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																																										
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																										
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																										
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2011	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2011	Equinox	Body	Body Control Module																																																										
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2011	Equinox	Body	Passenger Presence Module																																																										
L	2011	Equinox	Body	Instrument Cluster																																																										
L	2011	Equinox	Body	Radio																																																										
L	2011	Equinox	Body	Multimedia Player Interface Module																																																										
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2011	Equinox	Body	Liftgate Control Module																																																										
L	2011	Equinox	Body	Parking Assist Control Module																																																										
L	2011	Equinox	Body	Frontview Camera Module																																																										
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																																																										
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																	
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																	
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
L	2012	Captiva	Chassis	Electronic Brake Control Module																																																											
L	2012	Captiva	Chassis	Parking Brake Control Module																																																											
L	2012	Captiva	Body	Body Control Module																																																											
L	2012	Captiva	Body	Auxiliary Body Control Module																																																											
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2012	Captiva	Body	Instrument Cluster																																																											
L	2012	Captiva	Body	Headlamp Control Module																																																											
L	2012	Captiva	Body	HVAC Control Module																																																											
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																											
L	2012	Captiva	Body	Parking Assist Control Module																																																											
L	2012	Captiva	Body	Theft Deterrent Module																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																											
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module																																																											
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																																											
L	2012	Captiva Sport	Body	Body Control Module																																																											
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																											
L	2012	Captiva Sport	Body	HVAC Control Module																																																											
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																																											
L	2012	Captiva Sport	Body	Passenger Presence System																																																											
L	2012	Captiva Sport	Body	Radio																																																											
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																																											
L	2012	Captiva Sport	Body	Rollover Sensor																																																											
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																																																											
L	2012	Captiva Sport	Body	Theft Deterrent Module																																																											
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																											
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																											
L	2012	Equinox	Chassis	Electronic Brake Control Module																																																											
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2012	Equinox	Body	Body Control Module																																																											
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2012	Equinox	Body	Passenger Presence Module																																																											
L	2012	Equinox	Body	Instrument Cluster																																																											
L	2012	Equinox	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2012	Equinox	Body	Multimedia Player Interface Module																																																									
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																									
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																									
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																									
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																									
L	2012	Equinox	Body	Liftgate Control Module																																																									
L	2012	Equinox	Body	Parking Assist Control Module																																																									
L	2012	Equinox	Body	Frontview Camera Module																																																									
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																																									
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V																
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V	V			V																
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																									
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V																
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V	V			V																
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																									
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																									
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																									
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																									
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																									
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																									
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																									
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																									
L	2013	Captiva	Chassis	Parking Brake Control Module																																																									
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																									
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																									
L	2013	Captiva	Body	Auxiliary Body Control Module																																																									
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2013	Captiva	Body	Instrument Cluster																																																									
L	2013	Captiva	Body	Headlamp Control Module																																																									
L	2013	Captiva	Body	HVAC Control Module																																																									
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																									
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																									
L	2013	Captiva	Body	Theft Deterrent Module																																																									
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																									
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																									
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																									
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																									
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																									
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																									
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																																									
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																									
L	2013	Captiva Sport	Body	Body Control Module																																																									
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																									
L	2013	Captiva Sport	Body	Heated Seat Module																																																									
L	2013	Captiva Sport	Body	HVAC Control Module																																																									
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2013	Captiva Sport	Body	Park Assist Module																																																										
L	2013	Captiva Sport	Body	Passenger Presence System																																																											
L	2013	Captiva Sport	Body	Radio																																																											
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																											
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																																											
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																											
L	2013	Captiva Sport	Body	Theft Deterrent Module																																																											
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																											
L	2013	Equinox	Chassis	Electronic Brake Control Module																																																											
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2013	Equinox	Chassis	Power Steering Control Module																																																											
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																											
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2013	Equinox	Body	Passenger Presence Module																																																											
L	2013	Equinox	Body	Instrument Cluster																																																											
L	2013	Equinox	Body	Radio																																																											
L	2013	Equinox	Body	Rear Audio Control Module																																																											
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											
L	2013	Equinox	Body	Liftgate Control Module																																																											
L	2013	Equinox	Body	Front Seat Heating Control Module																																																											
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																											
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																											
L	2013	Equinox	Body	Parking Assist Control Module																																																											
L	2013	Equinox	Body	Frontview Camera Module																																																											
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																											
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																											
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																											
L	2014	Captiva (3GN)	Body	Body Control Module																																																											
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																											
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																											
L	2014	Captiva (3GN)	Body	Radio																																																											
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																											
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																											
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																											
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																										
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																	
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																	
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Captiva (Other)	Body	Instrument Cluster																																																										
L	2014	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2014	Captiva (Other)	Body	HVAC Control Module																																																										
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2014	Captiva (Other)	Body	Theft Deterrent Module																																																										
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2014	Equinox	Chassis	Power Steering Control Module																																																										
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Equinox	Body	Passenger Presence Module																																																										
L	2014	Equinox	Body	Instrument Cluster																																																										
L	2014	Equinox	Body	Radio																																																										
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2014	Equinox	Body	Liftgate Control Module																																																										
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Parking Assist Control Module																																																										
L	2014	Equinox	Body	Frontview Camera Module																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (3GN)	Body	Body Control Module																																																										
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																																										
L	2015	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2015	Captiva (3GN)	Body	Radio																																																										
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
L	2015	Captiva (3GN)	Body	HVAC Control Module																																																										
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V																	
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V	V			V																	
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V																	
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V	V			V																	
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (Other)	Body	Instrument Cluster																																																										
L	2015	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2015	Captiva (Other)	Body	HVAC Control Module																																																										
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																								
L	2015	Captiva (Other)	Body	Theft Deterrent Module																																																								
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																								
L	2015	Equinox	Chassis	Electronic Brake Control Module																																																								
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2015	Equinox	Chassis	Power Steering Control Module																																																								
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																																								
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																								
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2015	Equinox	Body	Passenger Presence Module																																																								
L	2015	Equinox	Body	Instrument Cluster																																																								
L	2015	Equinox	Body	Radio																																																								
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																																								
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																																								
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																																								
L	2015	Equinox	Body	Liftgate Control Module																																																								
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																								
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																								
L	2015	Equinox	Body	Parking Assist Control Module																																																								
L	2015	Equinox	Body	Frontview Camera Module																																																								
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																								
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																								
L	2016	Captiva (3GN)	Body	Body Control Module																																																								
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2016	Captiva (3GN)	Body	Instrument Cluster																																																								
L	2016	Captiva (3GN)	Body	Radio																																																								
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																								
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																								
L	2016	Captiva (3GN)	Body	HVAC Control Module																																																								
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																								
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																								
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																								
L	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																								
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																														V				V	V								V	V					V					V
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																														V				V	V								V	V					V					V
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																								
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V																
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V	V			V																
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																								
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V																
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V	V			V																
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																									
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																									
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																									
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																									
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																									
L	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																									
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																									
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																									
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																									
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2016	Captiva (Other)	Body	Instrument Cluster																																																									
L	2016	Captiva (Other)	Body	Headlamp Control Module																																																									
L	2016	Captiva (Other)	Body	Radio																																																									
L	2016	Captiva (Other)	Body	HVAC Control Module																																																									
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																									
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																									
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																									
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																									
L	2016	Captiva (Other)	Body	Theft Deterrent Module																																																									
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																																									
L	2016	Equinox	Chassis	Electronic Brake Control Module																																																									
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2016	Equinox	Chassis	Power Steering Control Module																																																									
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate																																																									
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																									
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2016	Equinox	Body	Passenger Presence Module																																																									
L	2016	Equinox	Body	Instrument Cluster																																																									
L	2016	Equinox	Body	Radio																																																									
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																																									
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																									
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																																																									
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																																																									
L	2016	Equinox	Body	Liftgate Control Module																																																									
L	2016	Equinox	Body	Seat Memory Control Module																																																									
L	2016	Equinox	Body	Right Side Object Detection Control Module																																																									
L	2016	Equinox	Body	Left Side Object Detection Control Module																																																									
L	2016	Equinox	Body	Parking Assist Control Module																																																									
L	2016	Equinox	Body	Frontview Camera Module																																																									
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
M	2004	ALL	Chassis	4WAL 3 Sensor																																																									
M	2004	ALL	Body	Body Control Module																																																									
M	2004	ALL	Body	Instrument Panel Cluster																																																									
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
M	2005	ALL	Chassis	4WAL 3 Sensor																																																									
M	2005	ALL	Body	Body Control Module																																																									
M	2005	ALL	Body	Instrument Panel Cluster																																																									
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
P	2007	ALL	Body	Theft Deterrent Module																																																									
R	2009	ALL	Powertrain	Engine Control Module																																																									
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2009	ALL	Powertrain	Transmission Control Module																																																									
R	2009	ALL	Chassis	Electronic Brake Control Module																																																									
R	2009	ALL	Body	Body Control Module																																																									
R	2009	ALL	Body	Digital Radio Receiver																																																									
R	2009	ALL	Body	Driver Door Switch																																																									
R	2009	ALL	Body	Heated Seat Module																																																									
R	2009	ALL	Body	HVAC Control Module Auto																																																									
R	2009	ALL	Body	HVAC Control Module Manual																																																									
R	2009	ALL	Body	Instrument Panel Cluster																																																									
R	2009	ALL	Body	Lift Gate Module																																																									
R	2009	ALL	Body	Park Assist Module																																																									
R	2009	ALL	Body	Passenger Door Switch																																																									
R	2009	ALL	Body	Passenger Presence System																																																									
R	2009	ALL	Body	Radio																																																									
R	2009	ALL	Body	Rear HVAC/RSA																																																									
R	2009	ALL	Body	Rollover Sensor																																																									
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2009	ALL	Body	Theft Deterrent Module																																																									
R	2010	ALL	Powertrain	Engine Control Module																																																									
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2010	ALL	Powertrain	Transmission Control Module																																																									
R	2010	ALL	Chassis	Electronic Brake Control Module																																																									
R	2010	ALL	Body	Body Control Module																																																									
R	2010	ALL	Body	Digital Radio Receiver																																																									
R	2010	ALL	Body	Driver Door Switch																																																									
R	2010	ALL	Body	Heated Seat Module																																																									
R	2010	ALL	Body	HVAC Control Module Auto																																																									
R	2010	ALL	Body	HVAC Control Module Manual																																																									
R	2010	ALL	Body	Instrument Panel Cluster																																																									
R	2010	ALL	Body	Lift Gate Module																																																									
R	2010	ALL	Body	Park Assist Module																																																									
R	2010	ALL	Body	Passenger Door Switch																																																									
R	2010	ALL	Body	Passenger Presence System																																																									
R	2010	ALL	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2010	ALL	Body	Rear HVAC/RSA																																																									
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2010	ALL	Body	Theft Deterrent Module																																																										
R	2011	ALL	Powertrain	Engine Control Module																																																										
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2011	ALL	Powertrain	Transmission Control Module																																																										
R	2011	ALL	Chassis	Electronic Brake Control Module																																																										
R	2011	ALL	Body	Body Control Module																																																										
R	2011	ALL	Body	Digital Radio Receiver																																																										
R	2011	ALL	Body	Driver Door Switch																																																										
R	2011	ALL	Body	Heated Seat Module																																																										
R	2011	ALL	Body	HVAC Control Module Auto																																																										
R	2011	ALL	Body	HVAC Control Module Manual																																																										
R	2011	ALL	Body	Instrument Panel Cluster																																																										
R	2011	ALL	Body	Lift Gate Module																																																										
R	2011	ALL	Body	Park Assist Module																																																										
R	2011	ALL	Body	Passenger Door Switch																																																										
R	2011	ALL	Body	Passenger Presence System																																																										
R	2011	ALL	Body	Radio																																																										
R	2011	ALL	Body	Rear HVAC/RSA																																																										
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2011	ALL	Body	Theft Deterrent Module																																																										
R	2012	ALL	Powertrain	Engine Control Module																																																										
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2012	ALL	Powertrain	Transmission Control Module																																																										
R	2012	ALL	Chassis	Electronic Brake Control Module																																																										
R	2012	ALL	Body	Body Control Module																																																										
R	2012	ALL	Body	Digital Radio Receiver																																																										
R	2012	ALL	Body	Driver Door Switch																																																										
R	2012	ALL	Body	Heated Seat Module																																																										
R	2012	ALL	Body	HVAC Control Module Auto																																																										
R	2012	ALL	Body	HVAC Control Module Manual																																																										
R	2012	ALL	Body	Instrument Panel Cluster																																																										
R	2012	ALL	Body	Lift Gate Module																																																										
R	2012	ALL	Body	Park Assist Module																																																										
R	2012	ALL	Body	Passenger Door Switch																																																										
R	2012	ALL	Body	Passenger Presence System																																																										
R	2012	ALL	Body	Radio																																																										
R	2012	ALL	Body	Rear HVAC/RSA																																																										
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2012	ALL	Body	Theft Deterrent Module																																																										
R	2013	ALL	Powertrain	Engine Control Module																																																										
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2013	ALL	Powertrain	Transmission Control Module																																																										
R	2013	ALL	Chassis	Electronic Brake Control Module																																																										
R	2013	ALL	Body	Body Control Module																																																										
R	2013	ALL	Body	Digital Radio Receiver																																																										
R	2013	ALL	Body	Driver Door Switch																																																										
R	2013	ALL	Body	Heated Seat Module																																																										
R	2013	ALL	Body	HVAC Control Module Auto																																																										
R	2013	ALL	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2013	ALL	Body	Instrument Panel Cluster																																																									
R	2013	ALL	Body	Left Side Object Detection Module																																																									
R	2013	ALL	Body	Lift Gate Module																																																									
R	2013	ALL	Body	Park Assist Module																																																									
R	2013	ALL	Body	Passenger Door Switch																																																									
R	2013	ALL	Body	Passenger Presence System																																																									
R	2013	ALL	Body	Radio																																																									
R	2013	ALL	Body	Rear HVAC/RSA																																																									
R	2013	ALL	Body	Right Side Object Detection Module																																																									
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2013	ALL	Body	Theft Deterrent Module																																																									
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
R	2014	Traverse	Powertrain	Chassis Control Module																																																									
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																									
R	2014	Traverse	Chassis	Electronic Brake Control Module																																																									
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																									
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																									
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
R	2014	Traverse	Body	Passenger Presence Module																																																									
R	2014	Traverse	Body	Instrument Cluster																																																									
R	2014	Traverse	Body	Radio																																																									
R	2014	Traverse	Body	Rear Audio Control Module																																																									
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																									
R	2014	Traverse	Body	Personal Audio Link Control Module																																																									
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																									
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																									
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																									
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																									
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																									
R	2014	Traverse	Body	Liftgate Control Module																																																									
R	2014	Traverse	Body	Seat Memory Control Module																																																									
R	2014	Traverse	Body	Front Seat Heating Control Module																																																									
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																									
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																									
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																									
R	2014	Traverse	Body	Parking Assist Control Module																																																									
R	2014	Traverse	Body	Frontview Camera Module																																																									
R	2014	Traverse	Body	Theft Deterrent Module																																																									
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																									
R	2015	Traverse	Chassis	Electronic Brake Control Module																																																									
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																									
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																									
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
R	2015	Traverse	Body	Passenger Presence Module																																																									
R	2015	Traverse	Body	Instrument Cluster																																																									
R	2015	Traverse	Body	Radio																																																									
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2015	Traverse	Body	Liftgate Control Module																																																										
R	2015	Traverse	Body	Seat Memory Control Module																																																										
R	2015	Traverse	Body	Front Seat Heating Control Module																																																										
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2015	Traverse	Body	Parking Assist Control Module																																																										
R	2015	Traverse	Body	Frontview Camera Module																																																										
R	2015	Traverse	Body	Theft Deterrent Module																																																										
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
R	2016	Traverse	Chassis	Electronic Brake Control Module																																																										
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Traverse	Body	Passenger Presence Module																																																										
R	2016	Traverse	Body	Instrument Cluster																																																										
R	2016	Traverse	Body	Radio																																																										
R	2016	Traverse	Body	Rear Audio Control Module																																																										
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																										
R	2016	Traverse	Body	Personal Audio Link Control Module																																																										
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																										
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Traverse	Body	Liftgate Control Module																																																										
R	2016	Traverse	Body	Seat Memory Control Module																																																										
R	2016	Traverse	Body	Front Seat Heating Control Module																																																										
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																										
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																										
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																										
R	2016	Traverse	Body	Parking Assist Control Module																																																										
R	2016	Traverse	Body	Frontview Camera Module																																																										
R	2016	Traverse	Body	Theft Deterrent Module																																																										
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	S10	Chassis	4WAL 3 Sensor																																																										
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																										
S	2004	S10	Body	Body Control Module																																																									
S	2004	S10	Body	Instrument Panel Cluster																																																										
S	2004	S10	Body	Base Radio																																																									
S	2004	S10	Body	Uplevel Radio																																																									
S	2004	S10	Body	Supplemental Inflatable Restraint																																																										
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																									
S	2004	Colorado	Chassis	ABS Without Traction Control																																																										
S	2004	Colorado	Chassis	ABS With Traction Control																																																										
S	2004	Colorado	Body	Body Control Module																																																										
S	2004	Colorado	Body	Instrument Panel Cluster																																																										
S	2004	Colorado	Body	OnStar																																																										
S	2004	Colorado	Body	Base Radio																																																										
S	2004	Colorado	Body	Uplevel Radio																																																										
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																										
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																										
S	2004	TrailBlazer	Body	Body Control Module																																																										
S	2004	TrailBlazer	Body	Driver Door Module																																																										
S	2004	TrailBlazer	Body	Driver Seat Module																																																										
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																																										
S	2004	TrailBlazer	Body	Lift Gate Module																																																										
S	2004	TrailBlazer	Body	OnStar																																																										
S	2004	TrailBlazer	Body	Passenger Door Module																																																										
S	2004	TrailBlazer	Body	Uplevel Radio																																																										
S	2004	TrailBlazer	Body	Navigation Radio																																																										
S	2004	TrailBlazer	Body	Rear Seat Audio																																																										
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																										
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																										
S	2004	TrailBlazer EXT	Body	Body Control Module																																																										
S	2004	TrailBlazer EXT	Body	Driver Door Module																																																										
S	2004	TrailBlazer EXT	Body	Driver Seat Module																																																										
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																										
S	2004	TrailBlazer EXT	Body	OnStar																																																										
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																																										
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																										
S	2004	TrailBlazer EXT	Body	Navigation Radio																																																										
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																										
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																										
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Blazer	Body	Body Control Module																																																										
S	2004	Blazer	Body	Heating and Air Conditioning																																																										
S	2004	Blazer	Body	Instrument Panel Cluster																																																										
S	2004	Blazer	Body	Memory Seat Module																																																										
S	2004	Blazer	Body	Base Radio																																																										
S	2004	Blazer	Body	Uplevel Radio																																																										
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																																										
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	SSR	Chassis	4WAL 3 Sensor																																																										
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																										
S	2004	SSR	Body	Amplifier (Bose)																																																										
S	2004	SSR	Body	Body Control Module																																																										
S	2004	SSR	Body	Driver Seat Module																																																										
S	2004	SSR	Body	Instrument Panel Cluster																																																										
S	2004	SSR	Body	Uplevel Radio																																																										
S	2004	SSR	Body	Remote Function Actuation																																																										
S	2004	SSR	Body	Roof and Door Module																																																										
S	2004	SSR	Body	Supplemental Inflatable Restraint																																																										
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2005	Colorado	Chassis	ABS Without Traction Control																																																										
S	2005	Colorado	Chassis	ABS With Traction Control																																																										
S	2005	Colorado	Body	Body Control Module																																																										
S	2005	Colorado	Body	Instrument Panel Cluster																																																										
S	2005	Colorado	Body	Base Radio																																																										
S	2005	Colorado	Body	Uplevel Radio																																																										
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																																										
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																										
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
S	2005	TrailBlazer	Body	Body Control Module																																																										
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2005	TrailBlazer	Body	Driver Door Module																																																										
S	2005	TrailBlazer	Body	Driver Seat Module																																																										
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2005	TrailBlazer	Body	Lift Gate Module																																																										
S	2005	TrailBlazer	Body	Passenger Door Module																																																											
S	2005	TrailBlazer	Body	Passenger Presence System																																																											
S	2005	TrailBlazer	Body	Uplevel Radio																																																											
S	2005	TrailBlazer	Body	Navigation Radio																																																											
S	2005	TrailBlazer	Body	Rear Seat Audio																																																											
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																											
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																											
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																											
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																											
S	2005	TrailBlazer EXT	Body	Body Control Module																																																											
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																											
S	2005	TrailBlazer EXT	Body	Driver Door Module																																																											
S	2005	TrailBlazer EXT	Body	Driver Seat Module																																																											
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																											
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																											
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																											
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																											
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																																											
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																											
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																											
S	2005	TrailBlazer EXT	Body	Navigation Radio																																																											
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																											
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																											
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																											
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																											
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																											
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																											
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																											
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																											
S	2005	Blazer	Body	Body Control Module																																																											
S	2005	Blazer	Body	Heating and Air Conditioning																																																											
S	2005	Blazer	Body	Instrument Panel Cluster																																																											
S	2005	Blazer	Body	Memory Seat Module																																																											
S	2005	Blazer	Body	Base Radio																																																											
S	2005	Blazer	Body	Uplevel Radio																																																											
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																																											
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2005	SSR	Chassis	4WAL 3 Sensor																																																											
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																											
S	2005	SSR	Body	Amplifier (Bose)																																																											
S	2005	SSR	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2005	SSR	Body	Driver Seat Module																																																										
S	2005	SSR	Body	Instrument Panel Cluster																																																											
S	2005	SSR	Body	Uplevel Radio																																																											
S	2005	SSR	Body	Remote Function Actuation																																																											
S	2005	SSR	Body	Roof and Door Module																																																											
S	2005	SSR	Body	Supplemental Inflatable Restraint																																																											
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2006	Colorado	Chassis	ABS Without Traction Control																																																											
S	2006	Colorado	Chassis	ABS With Traction Control																																																											
S	2006	Colorado	Body	Body Control Module																																																											
S	2006	Colorado	Body	Instrument Panel Cluster																																																											
S	2006	Colorado	Body	Passenger Presence System																																																											
S	2006	Colorado	Body	Base Radio																																																										
S	2006	Colorado	Body	Uplevel Radio																																																											
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																																											
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																																											
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																											
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																											
S	2006	TrailBlazer	Body	Body Control Module																																																											
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																											
S	2006	TrailBlazer	Body	Driver Door Module																																																											
S	2006	TrailBlazer	Body	Driver Seat Module																																																											
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																											
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																											
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																																											
S	2006	TrailBlazer	Body	Lift Gate Module																																																											
S	2006	TrailBlazer	Body	Passenger Door Module																																																											
S	2006	TrailBlazer	Body	Passenger Presence System																																																											
S	2006	TrailBlazer	Body	Uplevel Radio																																																											
S	2006	TrailBlazer	Body	Navigation Radio																																																											
S	2006	TrailBlazer	Body	Rear Seat Audio																																																											
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																											
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																											
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																											
S	2006	TrailBlazer EXT	Body	Body Control Module																																																											
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																											
S	2006	TrailBlazer EXT	Body	Driver Door Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2006	TrailBlazer EXT	Body	Driver Seat Module																																																										
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																										
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																																										
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																										
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																										
S	2006	TrailBlazer EXT	Body	Navigation Radio																																																										
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																										
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																										
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2006	SSR	Chassis	4WAL 3 Sensor																																																										
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																										
S	2006	SSR	Body	Amplifier (Bose)																																																										
S	2006	SSR	Body	Body Control Module																																																										
S	2006	SSR	Body	Driver Seat Module																																																										
S	2006	SSR	Body	Instrument Panel Cluster																																																										
S	2006	SSR	Body	Uplevel Radio																																																										
S	2006	SSR	Body	Remote Function Actuation																																																										
S	2006	SSR	Body	Roof and Door Module																																																										
S	2006	SSR	Body	Supplemental Inflatable Restraint																																																										
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																										
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																										
S	2007	Colorado	Body	Body Control Module																																																										
S	2007	Colorado	Body	Digital Radio Receiver																																																										
S	2007	Colorado	Body	Generator Battery Control Module																																																										
S	2007	Colorado	Body	Instrument Panel Cluster																																																										
S	2007	Colorado	Body	Passenger Presence System																																																										
S	2007	Colorado	Body	Base Radio																																																										
S	2007	Colorado	Body	Uplevel Radio																																																										
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																																										
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																										
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																										
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2007	Trailblazer	Body	Body Control Module																																																										
S	2007	Trailblazer	Body	Digital Radio Receiver																																																											
S	2007	Trailblazer	Body	Disc Player and Video Display																																																											
S	2007	Trailblazer	Body	Driver Door Module																																																											
S	2007	Trailblazer	Body	Driver Seat Module																																																												
S	2007	Trailblazer	Body	Generator Battery Control Module																																																												
S	2007	Trailblazer	Body	HVAC Control Module Auto																																																												
S	2007	Trailblazer	Body	HVAC Control Module Manual																																																												
S	2007	Trailblazer	Body	Instrument Panel Cluster																																																												
S	2007	Trailblazer	Body	Lift Gate Module																																																												
S	2007	Trailblazer	Body	Passenger Door Module																																																												
S	2007	Trailblazer	Body	Passenger Presence System																																																												
S	2007	Trailblazer	Body	Uplevel Radio																																																												
S	2007	Trailblazer	Body	Navigation Radio																																																												
S	2007	Trailblazer	Body	Rear Seat Audio																																																												
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																												
S	2007	Trailblazer	Body	Theft Deterrent Module																																																												
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																												
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2008	Colorado	Body	Body Control Module																																																												
S	2008	Colorado	Body	Digital Radio Receiver																																																												
S	2008	Colorado	Body	Generator Battery Control Module																																																												
S	2008	Colorado	Body	Instrument Panel Cluster																																																												
S	2008	Colorado	Body	Passenger Presence System																																																												
S	2008	Colorado	Body	Base Radio																																																												
S	2008	Colorado	Body	Uplevel Radio																																																												
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2008	Colorado	Body	Theft Deterrent Module																																																												
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																																												
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
S	2008	TrailBlazer	Body	Body Control Module																																																												
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																												
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																												
S	2008	TrailBlazer	Body	Driver Door Module																																																												
S	2008	TrailBlazer	Body	Driver Seat Module																																																												
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																												
S	2008	TrailBlazer	Body	HVAC Control Module Auto																																																												
S	2008	TrailBlazer	Body	HVAC Control Module Manual																																																												
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2008	TrailBlazer	Body	Lift Gate Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2008	TrailBlazer	Body	Passenger Door Module																																																										
S	2008	TrailBlazer	Body	Passenger Presence System																																																											
S	2008	TrailBlazer	Body	Uplevel Radio																																																											
S	2008	TrailBlazer	Body	Navigation Radio																																																											
S	2008	TrailBlazer	Body	Rear Seat Audio																																																											
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
S	2008	TrailBlazer	Body	Theft Deterrent Module																																																											
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																											
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																											
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																											
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																											
S	2009	Colorado	Chassis	Electronic Brake Control Module																																																											
S	2009	Colorado	Body	Body Control Module																																																											
S	2009	Colorado	Body	Digital Radio Receiver																																																											
S	2009	Colorado	Body	Generator Battery Control Module																																																											
S	2009	Colorado	Body	Instrument Panel Cluster																																																											
S	2009	Colorado	Body	Passenger Presence System																																																											
S	2009	Colorado	Body	Base Radio																																																											
S	2009	Colorado	Body	Uplevel Radio																																																											
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																																											
S	2009	Colorado	Body	Theft Deterrent Module																																																											
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																											
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																											
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																											
S	2009	TrailBlazer	Body	Body Control Module																																																											
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																											
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																											
S	2009	TrailBlazer	Body	Driver Door Module																																																											
S	2009	TrailBlazer	Body	Driver Seat Module																																																											
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																											
S	2009	TrailBlazer	Body	HVAC Control Module Auto																																																											
S	2009	TrailBlazer	Body	HVAC Control Module Manual																																																											
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																																											
S	2009	TrailBlazer	Body	Lift Gate Module																																																											
S	2009	TrailBlazer	Body	Passenger Door Module																																																											
S	2009	TrailBlazer	Body	Passenger Presence System																																																											
S	2009	TrailBlazer	Body	Uplevel Radio																																																											
S	2009	TrailBlazer	Body	Navigation Radio																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2009	TrailBlazer	Body	Rear Seat Audio																																																										
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2009	TrailBlazer	Body	Theft Deterrent Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2010	ALL	Chassis	Electronic Brake Control Module																																																										
S	2010	ALL	Body	Body Control Module																																																									
S	2010	ALL	Body	Digital Radio Receiver																																																									
S	2010	ALL	Body	Generator Battery Control Module																																																									
S	2010	ALL	Body	Instrument Panel Cluster																																																									
S	2010	ALL	Body	Passenger Presence System																																																									
S	2010	ALL	Body	Personal Audio Link Module																																																									
S	2010	ALL	Body	Base Radio																																																									
S	2010	ALL	Body	Uplevel Radio																																																									
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
S	2010	ALL	Body	Theft Deterrent Module																																																									
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																									
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																									
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
S	2011	ALL	Chassis	Electronic Brake Control Module																																																									
S	2011	ALL	Body	Body Control Module																																																								
S	2011	ALL	Body	Digital Radio Receiver																																																								
S	2011	ALL	Body	Generator Battery Control Module																																																								
S	2011	ALL	Body	Instrument Panel Cluster																																																								
S	2011	ALL	Body	Passenger Presence System																																																								
S	2011	ALL	Body	Personal Audio Link Module																																																								
S	2011	ALL	Body	Base Radio																																																								
S	2011	ALL	Body	Uplevel Radio																																																								
S	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
S	2011	ALL	Body	Theft Deterrent Module																																																								
S	2011	ALL	Body	Vehicle Comm. Interface Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																										
S	2012	Colorado (First Gen)	Body	Body Control Module																																																										
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																										
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																										
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																										
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																										
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																										
S	2012	Colorado (First Gen)	Body	Base Radio																																																										
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																										
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																										
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																										
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																										
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																										
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2012	Colorado (Second Gen)	Body	Body Control Module																																																										
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																										
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																										
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2012	S10	Powertrain	Transfer Case Control Module																																																										
S	2012	S10	Chassis	Electronic Brake Control Module																																																										
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2012	S10	Body	Body Control Module																																																										
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	S10	Body	Instrument Cluster																																																										
S	2012	S10	Body	Trailer Interface Control Module																																																										
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																										
S	2013	Colorado	Powertrain	Transfer Case Control Module																																																										
S	2013	Colorado	Chassis	Electronic Brake Control Module																																																										
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2013	Colorado	Body	Body Control Module																																																										
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Colorado	Body	Instrument Cluster																																																										
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2013	S10	Powertrain	Transfer Case Control Module																																																										
S	2013	S10	Chassis	Electronic Brake Control Module																																																										
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2013	S10	Body	Body Control Module																																																										
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	S10	Body	Instrument Cluster																																																										
S	2013	S10	Body	Trailer Interface Control Module																																																										
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																										
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																										
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																										
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2013	Trailblazer	Body	Body Control Module																																																										
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2013	Trailblazer	Body	Instrument Cluster																																																										
S	2013	Trailblazer	Body	Trailer Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2013	Trailblazer	Body	Parking Assist Control Module																																																									
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																												V	V											
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																												V	V											
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																												V	V											
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																												V	V											
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																										
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																										
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																										
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2014	Colorado	Body	Body Control Module																																																										
S	2014	Colorado	Body	Body Control Module																																																										
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Colorado	Body	Instrument Cluster																																																										
S	2014	Colorado	Body	Radio																																																										
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																										
S	2014	Colorado	Body	Parking Assist Control Module																																																										
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																												V	V											
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																												V	V											
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																												V	V											
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																												V	V											
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2014	S10	Powertrain	Transfer Case Control Module																																																										
S	2014	S10	Chassis	Electronic Brake Control Module																																																										
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2014	S10	Body	Body Control Module																																																										
S	2014	S10	Body	Body Control Module																																																										
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	S10	Body	Instrument Cluster																																																										
S	2014	S10	Body	Trailer Interface Control Module																																																										
S	2014	S10	Body	Radio																																																										
S	2014	S10	Body	Parking Assist Control Module																																																										
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																												V	V											
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																												V	V											
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																												V	V											
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																												V	V											
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																										
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																									
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2014	Trailblazer	Body	Body Control Module																																																									
S	2014	Trailblazer	Body	Body Control Module																																																									
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	Trailblazer	Body	Instrument Cluster																																																									
S	2014	Trailblazer	Body	Trailer Interface Control Module																																																									
S	2014	Trailblazer	Body	Parking Assist Control Module																																																									
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																													V	V										
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																													V	V										
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																													V	V										
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																													V	V										
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
S	2015	Colorado	Powertrain	Chassis Control Module																																																									
S	2015	Colorado	Powertrain	Transfer Case Control Module																																																									
S	2015	Colorado	Chassis	Electronic Brake Control Module																																																									
S	2015	Colorado	Chassis	Power Steering Control Module																																																									
S	2015	Colorado	Body	Body Control Module																																																									
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2015	Colorado	Body	Passenger Presence Module																																																									
S	2015	Colorado	Body	Radio																																																									
S	2015	Colorado	Body	Amplifier																																																									
S	2015	Colorado	Body	Human Machine Interface Control Module																																																									
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																																									
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																									
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																									
S	2015	Colorado	Body	Frontview Camera Module																																																									
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																													V	V										
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																													V	V										
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																													V	V										
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																													V	V										
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																									
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																									
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2015	Colorado (MMM)	Body	Body Control Module																																																									
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2015	Colorado (MMM)	Body	Instrument Cluster																																																										
S	2015	Colorado (MMM)	Body	Radio																																																										
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																										
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																														V	V										
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																														V	V										
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																														V	V										
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																														V	V										
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	S10	Powertrain	Transfer Case Control Module																																																										
S	2015	S10	Chassis	Electronic Brake Control Module																																																										
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	S10	Body	Body Control Module																																																										
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	S10	Body	Instrument Cluster																																																										
S	2015	S10	Body	Trailer Interface Control Module																																																										
S	2015	S10	Body	Radio																																																										
S	2015	S10	Body	Telematics Communication Interface Control Module																																																										
S	2015	S10	Body	Parking Assist Control Module																																																										
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																														V	V										
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																														V	V										
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																														V	V										
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																														V	V										
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																										
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																										
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	Trailblazer	Body	Body Control Module																																																										
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Trailblazer	Body	Instrument Cluster																																																										
S	2015	Trailblazer	Body	Trailer Interface Control Module																																																										
S	2015	Trailblazer	Body	Radio																																																										
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																										
S	2015	Trailblazer	Body	Parking Assist Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																									
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																										
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																										
S	2016	Colorado (1GC)	Body	Body Control Module																																																										
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																																										
S	2016	Colorado (1GC)	Body	Radio Controls																																																										
S	2016	Colorado (1GC)	Body	HVAC Controls																																																										
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																										
S	2016	Colorado (1GC)	Body	Radio																																																										
S	2016	Colorado (1GC)	Body	Amplifier																																																										
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																										
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																										
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																										
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																										
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																										
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																																										
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																														V					V									V	V												
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																														V					V									V	V												
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																														V				V	V									V	V						V						
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																														V				V	V									V	V						V						
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																										
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																										
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	Colorado (MMM)	Body	Body Control Module																																																										
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Colorado (MMM)	Body	Instrument Cluster																																																										
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																										
S	2016	Colorado (MMM)	Body	Radio																																																										
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																										
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																										
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																										
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																										
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																														V				V	V									V	V						V						
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																														V				V	V									V	V						V						
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	S10	Powertrain	Transfer Case Control Module																																																										
S	2016	S10	Chassis	Electronic Brake Control Module																																																										
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	S10	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2016	S10	Body	Instrument Cluster																																																										
S	2016	S10	Body	Trailer Interface Control Module																																																										
S	2016	S10	Body	Radio																																																										
S	2016	S10	Body	Telematics Communication Interface Control Module																																																										
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																										
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																										
S	2016	S10	Body	Parking Assist Control Module																																																										
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																													V	V										
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																													V	V										
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																														V				V	V									V	V					V					
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																														V				V	V									V	V					V					
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																										
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																										
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2016	Trailblazer	Body	Body Control Module																																																										
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2016	Trailblazer	Body	Instrument Cluster																																																										
S	2016	Trailblazer	Body	Trailer Interface Control Module																																																										
S	2016	Trailblazer	Body	Radio																																																										
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																										
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																										
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																										
S	2016	Trailblazer	Body	Parking Assist Control Module																																																										
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2004	S10	Chassis	4WAL 3 Sensor																																																										
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																										
T	2004	S10	Body	Body Control Module																																																										
T	2004	S10	Body	Instrument Panel Cluster																																																										
T	2004	S10	Body	Base Radio																																																										
T	2004	S10	Body	Uplevel Radio																																																										
T	2004	S10	Body	Supplemental Inflatable Restraint																																																										
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2004	Colorado	Chassis	ABS Without Traction Control																																																										
T	2004	Colorado	Chassis	ABS With Traction Control																																																										
T	2004	Colorado	Body	Body Control Module																																																										
T	2004	Colorado	Body	Instrument Panel Cluster																																																										
T	2004	Colorado	Body	OnStar																																																										
T	2004	Colorado	Body	Base Radio																																																										
T	2004	Colorado	Body	Uplevel Radio																																																										
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2004	Colorado	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer	Body	Body Control Module																																																										
T	2004	TrailBlazer	Body	Driver Door Module																																																										
T	2004	TrailBlazer	Body	Driver Seat Module																																																										
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2004	TrailBlazer	Body	Lift Gate Module																																																										
T	2004	TrailBlazer	Body	OnStar																																																										
T	2004	TrailBlazer	Body	Passenger Door Module																																																										
T	2004	TrailBlazer	Body	Uplevel Radio																																																										
T	2004	TrailBlazer	Body	Navigation Radio																																																										
T	2004	TrailBlazer	Body	Rear Seat Audio																																																										
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer EXT	Body	Body Control Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Seat Module																																																										
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2004	TrailBlazer EXT	Body	OnStar																																																										
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2004	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																										
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Blazer	Body	Body Control Module																																																										
T	2004	Blazer	Body	Heating and Air Conditioning																																																										
T	2004	Blazer	Body	Instrument Panel Cluster																																																										
T	2004	Blazer	Body	Memory Seat Module																																																										
T	2004	Blazer	Body	Base Radio																																																										
T	2004	Blazer	Body	Uplevel Radio																																																										
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																																										
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2005	Colorado	Chassis	ABS Without Traction Control																																																										
T	2005	Colorado	Chassis	ABS With Traction Control																																																										
T	2005	Colorado	Body	Body Control Module																																																										
T	2005	Colorado	Body	Instrument Panel Cluster																																																										
T	2005	Colorado	Body	Base Radio																																																										
T	2005	Colorado	Body	Uplevel Radio																																																										
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																										
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
T	2005	TrailBlazer	Body	Body Control Module																																																										
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2005	TrailBlazer	Body	Driver Door Module																																																										
T	2005	TrailBlazer	Body	Driver Seat Module																																																										
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2005	TrailBlazer	Body	Lift Gate Module																																																										
T	2005	TrailBlazer	Body	Passenger Door Module																																																										
T	2005	TrailBlazer	Body	Passenger Presence System																																																										
T	2005	TrailBlazer	Body	Uplevel Radio																																																										
T	2005	TrailBlazer	Body	Navigation Radio																																																										
T	2005	TrailBlazer	Body	Rear Seat Audio																																																										
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
T	2005	TrailBlazer EXT	Body	Body Control Module																																																										
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
T	2005	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2005	TrailBlazer EXT	Body	Driver Seat Module																																																										
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																										
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2005	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																										
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																										
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																										
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Blazer	Body	Body Control Module																																																										
T	2005	Blazer	Body	Heating and Air Conditioning																																																										
T	2005	Blazer	Body	Instrument Panel Cluster																																																										
T	2005	Blazer	Body	Memory Seat Module																																																										
T	2005	Blazer	Body	Base Radio																																																										
T	2005	Blazer	Body	Uplevel Radio																																																										
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																																										
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2006	Colorado	Chassis	ABS Without Traction Control																																																										
T	2006	Colorado	Chassis	ABS With Traction Control																																																										
T	2006	Colorado	Body	Body Control Module																																																										
T	2006	Colorado	Body	Instrument Panel Cluster																																																										
T	2006	Colorado	Body	Passenger Presence System																																																										
T	2006	Colorado	Body	Base Radio																																																										
T	2006	Colorado	Body	Uplevel Radio																																																										
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																																										
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																								
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																								
T	2006	TrailBlazer	Body	Body Control Module																																																								
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																								
T	2006	TrailBlazer	Body	Driver Door Module																																																								
T	2006	TrailBlazer	Body	Driver Seat Module																																																								
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																								
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																								
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																																								
T	2006	TrailBlazer	Body	Lift Gate Module																																																								
T	2006	TrailBlazer	Body	Passenger Door Module																																																								
T	2006	TrailBlazer	Body	Passenger Presence System																																																								
T	2006	TrailBlazer	Body	Uplevel Radio																																																								
T	2006	TrailBlazer	Body	Navigation Radio																																																								
T	2006	TrailBlazer	Body	Rear Seat Audio																																																								
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																								
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																								
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																								
T	2006	TrailBlazer EXT	Body	Body Control Module																																																								
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																								
T	2006	TrailBlazer EXT	Body	Driver Door Module																																																								
T	2006	TrailBlazer EXT	Body	Driver Seat Module																																																								
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																								
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																								
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																								
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																								
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																																								
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																								
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																								
T	2006	TrailBlazer EXT	Body	Navigation Radio																																																								
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																								
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																								
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																								
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																								
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																								
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																										
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																										
T	2007	Colorado	Body	Body Control Module																																																										
T	2007	Colorado	Body	Digital Radio Receiver																																																										
T	2007	Colorado	Body	Generator Battery Control Module																																																										
T	2007	Colorado	Body	Instrument Panel Cluster																																																										
T	2007	Colorado	Body	Passenger Presence System																																																										
T	2007	Colorado	Body	Base Radio																																																										
T	2007	Colorado	Body	Uplevel Radio																																																										
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																										
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																										
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2007	Trailblazer	Body	Body Control Module																																																										
T	2007	Trailblazer	Body	Digital Radio Receiver																																																										
T	2007	Trailblazer	Body	Disc Player and Video Display																																																										
T	2007	Trailblazer	Body	Driver Door Module																																																										
T	2007	Trailblazer	Body	Driver Seat Module																																																										
T	2007	Trailblazer	Body	Generator Battery Control Module																																																										
T	2007	Trailblazer	Body	HVAC Control Module Auto																																																										
T	2007	Trailblazer	Body	HVAC Control Module Manual																																																										
T	2007	Trailblazer	Body	Instrument Panel Cluster																																																										
T	2007	Trailblazer	Body	Lift Gate Module																																																										
T	2007	Trailblazer	Body	Passenger Door Module																																																										
T	2007	Trailblazer	Body	Passenger Presence System																																																										
T	2007	Trailblazer	Body	Uplevel Radio																																																										
T	2007	Trailblazer	Body	Navigation Radio																																																										
T	2007	Trailblazer	Body	Rear Seat Audio																																																										
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																										
T	2007	Trailblazer	Body	Theft Deterrent Module																																																										
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																										
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2008	Colorado	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2008	Colorado	Body	Digital Radio Receiver																																																									
T	2008	Colorado	Body	Generator Battery Control Module																																																										
T	2008	Colorado	Body	Instrument Panel Cluster																																																										
T	2008	Colorado	Body	Passenger Presence System																																																										
T	2008	Colorado	Body	Base Radio																																																										
T	2008	Colorado	Body	Uplevel Radio																																																										
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																																										
T	2008	Colorado	Body	Theft Deterrent Module																																																										
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																																										
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																										
T	2008	TrailBlazer	Body	Body Control Module																																																										
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																										
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2008	TrailBlazer	Body	Driver Door Module																																																										
T	2008	TrailBlazer	Body	Driver Seat Module																																																										
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																										
T	2008	TrailBlazer	Body	HVAC Control Module Auto																																																										
T	2008	TrailBlazer	Body	HVAC Control Module Manual																																																										
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																																										
T	2008	TrailBlazer	Body	Lift Gate Module																																																										
T	2008	TrailBlazer	Body	Passenger Door Module																																																										
T	2008	TrailBlazer	Body	Passenger Presence System																																																										
T	2008	TrailBlazer	Body	Uplevel Radio																																																										
T	2008	TrailBlazer	Body	Navigation Radio																																																										
T	2008	TrailBlazer	Body	Rear Seat Audio																																																										
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2008	TrailBlazer	Body	Theft Deterrent Module																																																										
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																										
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																										
T	2009	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2009	Colorado	Body	Body Control Module																																																										
T	2009	Colorado	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2009	Colorado	Body	Generator Battery Control Module																																																										
T	2009	Colorado	Body	Instrument Panel Cluster																																																											
T	2009	Colorado	Body	Passenger Presence System																																																											
T	2009	Colorado	Body	Base Radio																																																											
T	2009	Colorado	Body	Uplevel Radio																																																											
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																																											
T	2009	Colorado	Body	Theft Deterrent Module																																																											
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																											
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																											
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																											
T	2009	TrailBlazer	Body	Body Control Module																																																											
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																											
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																											
T	2009	TrailBlazer	Body	Driver Door Module																																																											
T	2009	TrailBlazer	Body	Driver Seat Module																																																											
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																											
T	2009	TrailBlazer	Body	HVAC Control Module Auto																																																											
T	2009	TrailBlazer	Body	HVAC Control Module Manual																																																											
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																																											
T	2009	TrailBlazer	Body	Lift Gate Module																																																											
T	2009	TrailBlazer	Body	Passenger Door Module																																																											
T	2009	TrailBlazer	Body	Passenger Presence System																																																											
T	2009	TrailBlazer	Body	Uplevel Radio																																																											
T	2009	TrailBlazer	Body	Navigation Radio																																																											
T	2009	TrailBlazer	Body	Rear Seat Audio																																																											
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
T	2009	TrailBlazer	Body	Theft Deterrent Module																																																											
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
T	2010	ALL	Chassis	Electronic Brake Control Module																																																											
T	2010	ALL	Body	Body Control Module																																																											
T	2010	ALL	Body	Digital Radio Receiver																																																											
T	2010	ALL	Body	Generator Battery Control Module																																																											
T	2010	ALL	Body	Instrument Panel Cluster																																																											
T	2010	ALL	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2010	ALL	Body	Personal Audio Link Module																																																									
T	2010	ALL	Body	Base Radio																																																									
T	2010	ALL	Body	Uplevel Radio																																																									
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2010	ALL	Body	Theft Deterrent Module																																																									
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																									
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																									
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																									
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																									
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																									
T	2011	ALL	Chassis	Electronic Brake Control Module																																																									
T	2011	ALL	Body	Body Control Module																																																									
T	2011	ALL	Body	Digital Radio Receiver																																																									
T	2011	ALL	Body	Generator Battery Control Module																																																									
T	2011	ALL	Body	Instrument Panel Cluster																																																									
T	2011	ALL	Body	Passenger Presence System																																																									
T	2011	ALL	Body	Personal Audio Link Module																																																									
T	2011	ALL	Body	Base Radio																																																									
T	2011	ALL	Body	Uplevel Radio																																																									
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2011	ALL	Body	Theft Deterrent Module																																																									
T	2011	ALL	Body	Vehicle Comm. Interface Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																									
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																									
T	2012	Colorado (First Gen)	Body	Body Control Module																																																									
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																									
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																									
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																									
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																									
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																									
T	2012	Colorado (First Gen)	Body	Base Radio																																																									
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																									
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																										
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2012	Colorado (Second Gen)	Body	Body Control Module																																																										
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																										
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																										
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2012	S10	Powertrain	Transfer Case Control Module																																																										
T	2012	S10	Chassis	Electronic Brake Control Module																																																										
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2012	S10	Body	Body Control Module																																																										
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2012	S10	Body	Instrument Cluster																																																										
T	2012	S10	Body	Trailer Interface Control Module																																																										
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2013	Colorado	Powertrain	Transfer Case Control Module																																																										
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2013	Colorado	Body	Body Control Module																																																									
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2013	Colorado	Body	Instrument Cluster																																																									
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																									
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																									
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																									
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																									
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																									
T	2013	S10	Powertrain	Transfer Case Control Module																																																									
T	2013	S10	Chassis	Electronic Brake Control Module																																																									
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2013	S10	Body	Body Control Module																																																									
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2013	S10	Body	Instrument Cluster																																																									
T	2013	S10	Body	Trailer Interface Control Module																																																									
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																									
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																									
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																									
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																									
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																									
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																									
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																									
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																									
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2013	Trailblazer	Body	Body Control Module																																																									
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2013	Trailblazer	Body	Instrument Cluster																																																									
T	2013	Trailblazer	Body	Trailer Interface Control Module																																																									
T	2013	Trailblazer	Body	Parking Assist Control Module																																																									
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																												V	V												
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																												V	V												
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																												V	V												
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																												V	V												
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																									
T	2014	Colorado	Powertrain	Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																									
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2014	Colorado	Body	Body Control Module																																																									
T	2014	Colorado	Body	Body Control Module																																																									
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2014	Colorado	Body	Instrument Cluster																																																									
T	2014	Colorado	Body	Radio																																																									
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																									
T	2014	Colorado	Body	Parking Assist Control Module																																																									
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																													V	V										
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																													V	V										
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																													V	V										
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																													V	V										
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2014	S10	Powertrain	Transfer Case Control Module																																																									
T	2014	S10	Chassis	Electronic Brake Control Module																																																									
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2014	S10	Body	Body Control Module																																																									
T	2014	S10	Body	Body Control Module																																																									
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2014	S10	Body	Instrument Cluster																																																									
T	2014	S10	Body	Trailer Interface Control Module																																																									
T	2014	S10	Body	Radio																																																									
T	2014	S10	Body	Parking Assist Control Module																																																									
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																													V	V										
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																													V	V										
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																													V	V										
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																													V	V										
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																									
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																									
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																									
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2014	Trailblazer	Body	Body Control Module																																																									
T	2014	Trailblazer	Body	Body Control Module																																																									
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2014	Trailblazer	Body	Instrument Cluster																																																									
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																									
T	2014	Trailblazer	Body	Parking Assist Control Module																																																									
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																											V	V								
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																											V	V								
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																											V	V								
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																											V	V								
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																				
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																				
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																				
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																				
T	2015	Colorado	Powertrain	Chassis Control Module																																																				
T	2015	Colorado	Powertrain	Transfer Case Control Module																																																				
T	2015	Colorado	Chassis	Electronic Brake Control Module																																																				
T	2015	Colorado	Chassis	Power Steering Control Module																																																				
T	2015	Colorado	Body	Body Control Module																																																				
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																				
T	2015	Colorado	Body	Passenger Presence Module																																																				
T	2015	Colorado	Body	Radio																																																				
T	2015	Colorado	Body	Amplifier																																																				
T	2015	Colorado	Body	Human Machine Interface Control Module																																																				
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																																				
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																				
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																				
T	2015	Colorado	Body	Frontview Camera Module																																																				
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																				
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																				
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																				
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																											V	V								
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																											V	V								
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																											V	V								
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																											V	V								
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																				
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																				
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																				
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																				
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																				
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																				
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																				
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																				
T	2015	Colorado (MMM)	Body	Body Control Module																																																				
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																				
T	2015	Colorado (MMM)	Body	Instrument Cluster																																																				
T	2015	Colorado (MMM)	Body	Radio																																																				
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																				
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																				
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																				
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																				
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																				
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																				
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																				
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																											V	V								
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																											V	V								
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																											V	V								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																												V	V									
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																							
T	2015	S10	Powertrain	Transfer Case Control Module																																																							
T	2015	S10	Chassis	Electronic Brake Control Module																																																						
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																						
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																						
T	2015	S10	Body	Body Control Module																																																						
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
T	2015	S10	Body	Instrument Cluster																																																						
T	2015	S10	Body	Trailer Interface Control Module																																																						
T	2015	S10	Body	Radio																																																						
T	2015	S10	Body	Telematics Communication Interface Control Module																																																						
T	2015	S10	Body	Parking Assist Control Module																																																						
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																												V	V									
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																												V	V									
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																												V	V									
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																												V	V									
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																						
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																						
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																						
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																						
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																						
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																						
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																						
T	2015	Trailblazer	Body	Body Control Module																																																						
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
T	2015	Trailblazer	Body	Instrument Cluster																																																						
T	2015	Trailblazer	Body	Trailer Interface Control Module																																																						
T	2015	Trailblazer	Body	Radio																																																						
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																						
T	2015	Trailblazer	Body	Parking Assist Control Module																																																						
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																						
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																						
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																						
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																						
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																						
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																						
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																						
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																						
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																						
T	2016	Colorado (1GC)	Body	Body Control Module																																																						
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																																						
T	2016	Colorado (1GC)	Body	Radio Controls																																																						
T	2016	Colorado (1GC)	Body	HVAC Controls																																																						
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																						
T	2016	Colorado (1GC)	Body	Radio																																																						
T	2016	Colorado (1GC)	Body	Amplifier																																																						
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																						

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																								
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																								
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																								
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																								
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																								
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																														V					V									V	V											
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																														V					V									V	V											
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																														V				V	V									V	V					V					
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																														V				V	V									V	V					V					
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																								
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																								
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2016	Colorado (MMM)	Body	Body Control Module																																																								
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																								
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																								
T	2016	Colorado (MMM)	Body	Radio																																																								
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																								
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																								
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																								
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																								
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																								
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																														V				V	V									V	V					V					
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																														V				V	V									V	V					V					
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
T	2016	S10	Powertrain	Transfer Case Control Module																																																								
T	2016	S10	Chassis	Electronic Brake Control Module																																																								
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2016	S10	Body	Body Control Module																																																								
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2016	S10	Body	Instrument Cluster																																																								
T	2016	S10	Body	Trailer Interface Control Module																																																								
T	2016	S10	Body	Radio																																																								
T	2016	S10	Body	Telematics Communication Interface Control Module																																																								
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																								
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																								
T	2016	S10	Body	Parking Assist Control Module																																																								
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																												V	V											
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																												V	V											
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																														V				V	V									V	V					V					
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																														V				V	V									V	V					V					

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																									
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																									
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2016	Trailblazer	Body	Body Control Module																																																									
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2016	Trailblazer	Body	Instrument Cluster																																																									
T	2016	Trailblazer	Body	Trailer Interface Control Module																																																									
T	2016	Trailblazer	Body	Radio																																																									
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																									
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																									
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																									
T	2016	Trailblazer	Body	Parking Assist Control Module																																																									
V	2009	ALL	Powertrain	Engine Control Module																																																									
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2009	ALL	Powertrain	Rear Drive System																																																									
V	2009	ALL	Powertrain	Transmission Control Module																																																									
V	2009	ALL	Chassis	Electronic Brake Control Module																																																									
V	2009	ALL	Body	Body Control Module																																																									
V	2009	ALL	Body	Digital Radio Receiver																																																									
V	2009	ALL	Body	Driver Door Switch																																																									
V	2009	ALL	Body	Heated Seat Module																																																									
V	2009	ALL	Body	HVAC Control Module Auto																																																									
V	2009	ALL	Body	HVAC Control Module Manual																																																									
V	2009	ALL	Body	Instrument Panel Cluster																																																									
V	2009	ALL	Body	Lift Gate Module																																																									
V	2009	ALL	Body	Park Assist Module																																																									
V	2009	ALL	Body	Passenger Door Switch																																																									
V	2009	ALL	Body	Passenger Presence System																																																									
V	2009	ALL	Body	Radio																																																									
V	2009	ALL	Body	Rear HVAC/RSA																																																									
V	2009	ALL	Body	Rollover Sensor																																																									
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2009	ALL	Body	Theft Deterrent Module																																																									
V	2010	ALL	Powertrain	Engine Control Module																																																									
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2010	ALL	Powertrain	Rear Drive System																																																									
V	2010	ALL	Powertrain	Transmission Control Module																																																									
V	2010	ALL	Chassis	Electronic Brake Control Module																																																									
V	2010	ALL	Body	Body Control Module																																																									
V	2010	ALL	Body	Digital Radio Receiver																																																									
V	2010	ALL	Body	Driver Door Switch																																																									
V	2010	ALL	Body	Heated Seat Module																																																									
V	2010	ALL	Body	HVAC Control Module Auto																																																									
V	2010	ALL	Body	HVAC Control Module Manual																																																									
V	2010	ALL	Body	Instrument Panel Cluster																																																									
V	2010	ALL	Body	Lift Gate Module																																																									
V	2010	ALL	Body	Park Assist Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
V	2010	ALL	Body	Passenger Door Switch																																																									
V	2010	ALL	Body	Passenger Presence System																																																									
V	2010	ALL	Body	Radio																																																									
V	2010	ALL	Body	Rear HVAC/RSA																																																									
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2010	ALL	Body	Theft Deterrent Module																																																									
V	2011	ALL	Powertrain	Engine Control Module																																																									
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2011	ALL	Powertrain	Rear Drive System																																																									
V	2011	ALL	Powertrain	Transmission Control Module																																																									
V	2011	ALL	Chassis	Electronic Brake Control Module																																																									
V	2011	ALL	Body	Body Control Module																																																									
V	2011	ALL	Body	Digital Radio Receiver																																																									
V	2011	ALL	Body	Driver Door Switch																																																									
V	2011	ALL	Body	Heated Seat Module																																																									
V	2011	ALL	Body	HVAC Control Module Auto																																																									
V	2011	ALL	Body	HVAC Control Module Manual																																																									
V	2011	ALL	Body	Instrument Panel Cluster																																																									
V	2011	ALL	Body	Lift Gate Module																																																									
V	2011	ALL	Body	Park Assist Module																																																									
V	2011	ALL	Body	Passenger Door Switch																																																									
V	2011	ALL	Body	Passenger Presence System																																																									
V	2011	ALL	Body	Radio																																																									
V	2011	ALL	Body	Rear HVAC/RSA																																																									
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2011	ALL	Body	Theft Deterrent Module																																																									
V	2012	ALL	Powertrain	Engine Control Module																																																									
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2012	ALL	Powertrain	Rear Drive System																																																									
V	2012	ALL	Powertrain	Transmission Control Module																																																									
V	2012	ALL	Chassis	Electronic Brake Control Module																																																									
V	2012	ALL	Body	Body Control Module																																																									
V	2012	ALL	Body	Digital Radio Receiver																																																									
V	2012	ALL	Body	Driver Door Switch																																																									
V	2012	ALL	Body	Heated Seat Module																																																									
V	2012	ALL	Body	HVAC Control Module Auto																																																									
V	2012	ALL	Body	HVAC Control Module Manual																																																									
V	2012	ALL	Body	Instrument Panel Cluster																																																									
V	2012	ALL	Body	Lift Gate Module																																																									
V	2012	ALL	Body	Park Assist Module																																																									
V	2012	ALL	Body	Passenger Door Switch																																																									
V	2012	ALL	Body	Passenger Presence System																																																									
V	2012	ALL	Body	Radio																																																									
V	2012	ALL	Body	Rear HVAC/RSA																																																									
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2012	ALL	Body	Theft Deterrent Module																																																									
V	2013	ALL	Powertrain	Engine Control Module																																																									
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2013	ALL	Powertrain	Rear Drive System																																																									
V	2013	ALL	Powertrain	Transmission Control Module																																																									
V	2013	ALL	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
V	2013	ALL	Body	Body Control Module																																																										
V	2013	ALL	Body	Digital Radio Receiver																																																											
V	2013	ALL	Body	Driver Door Switch																																																											
V	2013	ALL	Body	Heated Seat Module																																																											
V	2013	ALL	Body	HVAC Control Module Auto																																																											
V	2013	ALL	Body	HVAC Control Module Manual																																																											
V	2013	ALL	Body	Instrument Panel Cluster																																																											
V	2013	ALL	Body	Left Side Object Detection Module																																																											
V	2013	ALL	Body	Lift Gate Module																																																											
V	2013	ALL	Body	Park Assist Module																																																											
V	2013	ALL	Body	Passenger Door Switch																																																											
V	2013	ALL	Body	Passenger Presence System																																																											
V	2013	ALL	Body	Radio																																																											
V	2013	ALL	Body	Rear HVAC/RSA																																																											
V	2013	ALL	Body	Right Side Object Detection Module																																																											
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2013	ALL	Body	Theft Deterrent Module																																																											
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2014	Traverse	Powertrain	Chassis Control Module																																																											
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																											
V	2014	Traverse	Chassis	Electronic Brake Control Module																																																											
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																											
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																											
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
V	2014	Traverse	Body	Passenger Presence Module																																																											
V	2014	Traverse	Body	Instrument Cluster																																																											
V	2014	Traverse	Body	Radio																																																											
V	2014	Traverse	Body	Rear Audio Control Module																																																											
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																											
V	2014	Traverse	Body	Personal Audio Link Control Module																																																											
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																											
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																											
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																											
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																											
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																											
V	2014	Traverse	Body	Liftgate Control Module																																																											
V	2014	Traverse	Body	Seat Memory Control Module																																																											
V	2014	Traverse	Body	Front Seat Heating Control Module																																																											
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																											
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																											
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																											
V	2014	Traverse	Body	Parking Assist Control Module																																																											
V	2014	Traverse	Body	Frontview Camera Module																																																											
V	2014	Traverse	Body	Theft Deterrent Module																																																											
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																											
V	2015	Traverse	Chassis	Electronic Brake Control Module																																																											
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Traverse	Body	Passenger Presence Module																																																										
V	2015	Traverse	Body	Instrument Cluster																																																										
V	2015	Traverse	Body	Radio																																																										
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2015	Traverse	Body	Liftgate Control Module																																																										
V	2015	Traverse	Body	Seat Memory Control Module																																																										
V	2015	Traverse	Body	Front Seat Heating Control Module																																																										
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2015	Traverse	Body	Parking Assist Control Module																																																										
V	2015	Traverse	Body	Frontview Camera Module																																																										
V	2015	Traverse	Body	Theft Deterrent Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Traverse	Chassis	Electronic Brake Control Module																																																										
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Traverse	Body	Passenger Presence Module																																																										
V	2016	Traverse	Body	Instrument Cluster																																																										
V	2016	Traverse	Body	Radio																																																										
V	2016	Traverse	Body	Rear Audio Control Module																																																										
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2016	Traverse	Body	Personal Audio Link Control Module																																																										
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																										
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Liftgate Control Module																																																										
V	2016	Traverse	Body	Seat Memory Control Module																																																										
V	2016	Traverse	Body	Front Seat Heating Control Module																																																										
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2016	Traverse	Body	Parking Assist Control Module																																																										
V	2016	Traverse	Body	Frontview Camera Module																																																										
V	2016	Traverse	Body	Theft Deterrent Module																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																											
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission													V	V																																											
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V									V			V	V	V	V	V	V	V	V	V	V	V			V																

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																											
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																											
A	2011	Orlando	Chassis	Parking Brake Control Module																																																											
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2011	Orlando	Chassis	Power Steering Control Module																																																											
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2011	Orlando	Body	Body Control Module																																																											
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2011	Orlando	Body	Instrument Cluster																																																											
A	2011	Orlando	Body	Trailer Interface Control Module																																																											
A	2011	Orlando	Body	Radio																																																											
A	2011	Orlando	Body	Multimedia Player Interface Module																																																											
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
A	2011	Orlando	Body	Keyless Entry Control Module																																																											
A	2011	Orlando	Body	Parking Assist Control Module																																																											
A	2011	Orlando	Body	Steering Column Lock Control Module																																																											
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																												
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission													V	V																																												
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																											
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																		
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V									V			V	V	V	V	V	V	V	V	V	V	V			V																	
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																											
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																											
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																											
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																											
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																											
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																											
A	2012	Orlando	Chassis	Parking Brake Control Module																																																											
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2012	Orlando	Chassis	Power Steering Control Module																																																											
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2012	Orlando	Body	Body Control Module																																																											
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2012	Orlando	Body	Instrument Cluster																																																											
A	2012	Orlando	Body	Trailer Interface Control Module																																																											
A	2012	Orlando	Body	Radio																																																											
A	2012	Orlando	Body	Multimedia Player Interface Module																																																											
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
A	2012	Orlando	Body	Keyless Entry Control Module																																																											
A	2012	Orlando	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2012	Orlando	Body	Steering Column Lock Control Module																																																									
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission													V	V																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																									
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V																
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V									V			V	V	V	V	V	V	V	V	V	V	V			V																
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																									
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																									
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																									
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																									
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																									
A	2013	Orlando	Chassis	Parking Brake Control Module																																																									
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2013	Orlando	Chassis	Power Steering Control Module																																																									
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2013	Orlando	Body	Body Control Module																																																									
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2013	Orlando	Body	Instrument Cluster																																																									
A	2013	Orlando	Body	Radio																																																									
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																									
A	2013	Orlando	Body	Multimedia Player Interface Module																																																									
A	2013	Orlando	Body	Mobile Telephone Control Module																																																									
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
A	2013	Orlando	Body	Front Seat Heating Control Module																																																									
A	2013	Orlando	Body	Keyless Entry Control Module																																																									
A	2013	Orlando	Body	Parking Assist Control Module																																																									
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission											V												V	V	V																																
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission											V												V	V	V																																
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																									
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission													V	V																																									
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission														V									V			V	V	V	V	V	V	V	V	V	V	V			V																
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V									V			V	V	V	V	V	V	V	V	V	V	V			V																

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																								
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																								
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																								
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2014	Orlando	Chassis	Power Steering Control Module																																																								
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2014	Orlando	Body	Body Control Module																																																								
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2014	Orlando	Body	Instrument Cluster																																																								
A	2014	Orlando	Body	Radio																																																								
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																								
A	2014	Orlando	Body	Multimedia Player Interface Module																																																								
A	2014	Orlando	Body	Mobile Telephone Control Module																																																								
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																								
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																								
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																								
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																								
A	2014	Orlando	Body	Front Seat Heating Control Module																																																								
A	2014	Orlando	Body	Rear Seat Heating Control Module																																																								
A	2014	Orlando	Body	Keyless Entry Control Module																																																								
A	2014	Orlando	Body	Parking Assist Control Module																																																								
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																															
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																															
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																								
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission													V	V																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V																
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V																
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																								
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																								
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																								
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2015	Orlando	Chassis	Power Steering Control Module																																																								
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2015	Orlando	Body	Body Control Module																																																								
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2015	Orlando	Body	Instrument Cluster																																																								
A	2015	Orlando	Body	Radio																																																								
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																								
A	2015	Orlando	Body	Mobile Telephone Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																									
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
A	2015	Orlando	Body	Front Seat Heating Control Module																																																									
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																									
A	2015	Orlando	Body	Keyless Entry Control Module																																																									
A	2015	Orlando	Body	Parking Assist Control Module																																																									
A	2015	Orlando	Body	Frontview Camera Module																																																									
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																	
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																	
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																									
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																									
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																										
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission													V	V																																										
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																									
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																		
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V			V																		
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																									
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																									
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2016	Orlando	Chassis	Power Steering Control Module																																																									
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2016	Orlando	Body	Body Control Module																																																									
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2016	Orlando	Body	Instrument Cluster																																																									
A	2016	Orlando	Body	Radio																																																									
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																									
A	2016	Orlando	Body	Multimedia Player Interface Module																																																									
A	2016	Orlando	Body	Mobile Telephone Control Module																																																									
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																									
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
A	2016	Orlando	Body	Front Seat Heating Control Module																																																									
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																									
A	2016	Orlando	Body	Keyless Entry Control Module																																																									
A	2016	Orlando	Body	Parking Assist Control Module																																																									
A	2016	Orlando	Body	Frontview Camera Module																																																									
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																											V																														
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																											V																														
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																											V																														
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																											V																														

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																												V																													
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																												V																													
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																									
C	2009	N200	Chassis	Electronic Brake Control Module																																																									
C	2009	N200	Body	Supplemental Inflatable Restraint																																																									
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																									
C	2009	N300	Chassis	Electronic Brake Control Module																																																									
C	2009	N300	Body	Supplemental Inflatable Restraint																																																									
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																									
C	2010	N200	Chassis	Electronic Brake Control Module																																																									
C	2010	N200	Body	Supplemental Inflatable Restraint																																																									
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																									
C	2010	N300	Chassis	Electronic Brake Control Module																																																									
C	2010	N300	Body	Supplemental Inflatable Restraint																																																									
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																									
C	2011	N200	Chassis	Electronic Brake Control Module																																																									
C	2011	N200	Body	Supplemental Inflatable Restraint																																																									
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																									
C	2011	N300	Chassis	Electronic Brake Control Module																																																									
C	2011	N300	Body	Supplemental Inflatable Restraint																																																									
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																									
C	2012	N200	Chassis	Electronic Brake Control Module																																																									
C	2012	N200	Body	Supplemental Inflatable Restraint																																																									
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																									
C	2012	N300	Chassis	Electronic Brake Control Module																																																									
C	2012	N300	Body	Supplemental Inflatable Restraint																																																									
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module																																																									
C	2013	N300	Chassis	Electronic Brake Control Module																																																									
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module																																																									
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																																									
C	2014	N300	Chassis	Electronic Brake Control Module																																																									
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module																																																									
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																																									
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																																									
C	2015	Max	Chassis	Electronic Brake Control Module																																																									
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module																																																									
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																																									
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																																									
C	2015	Move	Chassis	Electronic Brake Control Module																																																									
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module																																																									
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																																									
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																																									
C	2015	N300	Chassis	Electronic Brake Control Module																																																									
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																																										
C	2016	Max	Chassis	Electronic Brake Control Module																																																										
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																																										
C	2016	Move	Chassis	Electronic Brake Control Module																																																										
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																																										
C	2016	N300	Chassis	Electronic Brake Control Module																																																										
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																										
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																										
M	2015	City Express	Chassis	Electronic Brake Control Module																																																										
M	2015	City Express	Chassis	Power Steering Control Module																																																										
M	2015	City Express	Body	Body Control Module																																																										
M	2015	City Express	Body	Underhood Fuse Block																																																										
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	City Express	Body	Instrument Cluster																																																										
M	2015	City Express	Body	Tire Pressure Indicator Module																																																										
M	2015	City Express	Body	Radio																																																										
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																										
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																										
M	2016	City Express	Chassis	Electronic Brake Control Module																																																										
M	2016	City Express	Chassis	Power Steering Control Module																																																										
M	2016	City Express	Body	Body Control Module																																																										
M	2016	City Express	Body	Underhood Fuse Block																																																										
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	City Express	Body	Instrument Cluster																																																										
M	2016	City Express	Body	Tire Pressure Indicator Module																																																										
M	2016	City Express	Body	Radio																																																										
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																											
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission													V	V																																											
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V									V			V	V	V	V	V	V	V	V	V	V	V			V															
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2011	Orlando	Chassis	Parking Brake Control Module																																																										
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2011	Orlando	Chassis	Power Steering Control Module																																																										
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
P	2011	Orlando	Body	Body Control Module																																																									
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2011	Orlando	Body	Instrument Cluster																																																									
P	2011	Orlando	Body	Trailer Interface Control Module																																																									
P	2011	Orlando	Body	Radio																																																									
P	2011	Orlando	Body	Multimedia Player Interface Module																																																									
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
P	2011	Orlando	Body	Keyless Entry Control Module																																																									
P	2011	Orlando	Body	Parking Assist Control Module																																																									
P	2011	Orlando	Body	Steering Column Lock Control Module																																																									
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission													V	V																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V			V																	
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V									V			V	V	V	V	V	V	V	V	V	V			V																	
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																									
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																									
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																									
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																									
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																																									
P	2012	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2012	Orlando	Chassis	Parking Brake Control Module																																																									
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2012	Orlando	Chassis	Power Steering Control Module																																																									
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2012	Orlando	Body	Body Control Module																																																									
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2012	Orlando	Body	Instrument Cluster																																																									
P	2012	Orlando	Body	Trailer Interface Control Module																																																									
P	2012	Orlando	Body	Radio																																																									
P	2012	Orlando	Body	Multimedia Player Interface Module																																																									
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
P	2012	Orlando	Body	Keyless Entry Control Module																																																									
P	2012	Orlando	Body	Parking Assist Control Module																																																									
P	2012	Orlando	Body	Steering Column Lock Control Module																																																									
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission											V											V	V	V																																	
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission											V											V	V	V																																	
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																										
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission													V	V																																										
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																								
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V																
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V									V			V	V	V	V	V	V	V	V	V	V	V			V																
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																								
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																								
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																								
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																								
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																								
P	2013	Orlando	Chassis	Parking Brake Control Module																																																								
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2013	Orlando	Chassis	Power Steering Control Module																																																								
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2013	Orlando	Body	Body Control Module																																																								
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2013	Orlando	Body	Instrument Cluster																																																								
P	2013	Orlando	Body	Radio																																																								
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																								
P	2013	Orlando	Body	Multimedia Player Interface Module																																																								
P	2013	Orlando	Body	Mobile Telephone Control Module																																																								
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																								
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																								
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																								
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																								
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																								
P	2013	Orlando	Body	Front Seat Heating Control Module																																																								
P	2013	Orlando	Body	Keyless Entry Control Module																																																								
P	2013	Orlando	Body	Parking Assist Control Module																																																								
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission											V												V	V	V																																
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission											V												V	V	V																																
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission													V	V																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V																
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V																
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																								
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																								
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																								
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
P	2014	Orlando	Chassis	Power Steering Control Module																																																												
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2014	Orlando	Body	Body Control Module																																																												
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2014	Orlando	Body	Instrument Cluster																																																												
P	2014	Orlando	Body	Radio																																																												
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																												
P	2014	Orlando	Body	Multimedia Player Interface Module																																																												
P	2014	Orlando	Body	Mobile Telephone Control Module																																																												
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																												
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																												
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																												
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																												
P	2014	Orlando	Body	Front Seat Heating Control Module																																																												
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																												
P	2014	Orlando	Body	Keyless Entry Control Module																																																												
P	2014	Orlando	Body	Parking Assist Control Module																																																												
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																			
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																			
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																												
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																												
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission													V	V																																												
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V																		
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission														V										V			V	V	V	V	V	V	V	V	V	V	V			V																		
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																												
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																												
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																												
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																												
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2015	Orlando	Chassis	Power Steering Control Module																																																												
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2015	Orlando	Body	Body Control Module																																																												
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2015	Orlando	Body	Instrument Cluster																																																												
P	2015	Orlando	Body	Radio																																																												
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																												
P	2015	Orlando	Body	Mobile Telephone Control Module																																																												
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																												
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																												
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																												
P	2015	Orlando	Body	Front Seat Heating Control Module																																																												
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																												
P	2015	Orlando	Body	Keyless Entry Control Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
P	2015	Orlando	Body	Parking Assist Control Module																																																									
P	2015	Orlando	Body	Frontview Camera Module																																																									
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission											V												V	V	V																																
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission											V												V	V	V																																
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																									
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																									
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission													V	V																																										
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission													V	V																																										
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																									
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																												V	V	V	V	V	V	V	V	V	V			V																	
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																												V	V	V	V	V	V	V	V	V	V			V																	
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																									
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2016	Orlando	Chassis	Power Steering Control Module																																																									
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2016	Orlando	Body	Body Control Module																																																									
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2016	Orlando	Body	Instrument Cluster																																																									
P	2016	Orlando	Body	Radio																																																									
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																									
P	2016	Orlando	Body	Multimedia Player Interface Module																																																									
P	2016	Orlando	Body	Mobile Telephone Control Module																																																									
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																																									
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
P	2016	Orlando	Body	Front Seat Heating Control Module																																																									
P	2016	Orlando	Body	Rear Seat Heating Control Module																																																									
P	2016	Orlando	Body	Keyless Entry Control Module																																																									
P	2016	Orlando	Body	Parking Assist Control Module																																																									
P	2016	Orlando	Body	Frontview Camera Module																																																									
U	2004	ALL	Powertrain	Engine Control Module																																																									
U	2004	ALL	Powertrain	Transmission Control Module																																																									
U	2004	ALL	Body	Digital Radio Receiver																																																									
U	2004	ALL	Body	Driver Information Center																																																									
U	2004	ALL	Body	Instrument Panel Cluster																																																									
U	2004	ALL	Body	Radio																																																									
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
U	2004	ALL	Body	Vehicle Theft Deterrent																																																									
U	2005	ALL	Powertrain	Engine Control Module																																																									
U	2005	ALL	Powertrain	Transmission Control Module																																																									
U	2005	ALL	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
U	2005	ALL	Body	Body Control Module																																																										
U	2005	ALL	Body	Disc Player and Video																																																										
U	2005	ALL	Body	Digital Radio Receiver																																																										
U	2005	ALL	Body	HVAC Control Module																																																										
U	2005	ALL	Body	Instrument Panel Cluster																																																										
U	2005	ALL	Body	Left Power Sliding Door Module																																																										
U	2005	ALL	Body	Mobile Digital Media																																																										
U	2005	ALL	Body	Navigation Radio																																																										
U	2005	ALL	Body	Navigation Radio																																																										
U	2005	ALL	Body	Radio																																																										
U	2005	ALL	Body	Right Power Sliding Door Module																																																										
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																										
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																										
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																										
U	2006	ALL	Chassis	Electronic Brake Control Module																																																										
U	2006	ALL	Body	Body Control Module																																																										
U	2006	ALL	Body	Disc Player and Video																																																										
U	2006	ALL	Body	Digital Radio Receiver																																																										
U	2006	ALL	Body	HVAC Control Module																																																										
U	2006	ALL	Body	Instrument Panel Cluster																																																										
U	2006	ALL	Body	Left Power Sliding Door Module																																																										
U	2006	ALL	Body	Mobile Digital Media																																																										
U	2006	ALL	Body	Navigation Radio																																																										
U	2006	ALL	Body	Navigation Radio																																																										
U	2006	ALL	Body	Radio																																																										
U	2006	ALL	Body	Right Power Sliding Door Module																																																										
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																										
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
U	2007	ALL	Chassis	Electronic Brake Control Module																																																										
U	2007	ALL	Body	Body Control Module																																																										
U	2007	ALL	Body	Digital Radio Receiver																																																										
U	2007	ALL	Body	Disc Player and Video Display																																																										
U	2007	ALL	Body	HVAC Control Module																																																										
U	2007	ALL	Body	Left Power Sliding Door Module																																																										
U	2007	ALL	Body	Mobile Digital Media																																																										
U	2007	ALL	Body	Radio																																																										
U	2007	ALL	Body	Navigation Radio																																																										
U	2007	ALL	Body	Right Power Sliding Door Module																																																										
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																										
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
U	2008	ALL	Chassis	Electronic Brake Control Module																																																										
U	2008	ALL	Body	Body Control Module																																																										
U	2008	ALL	Body	Digital Radio Receiver																																																										
U	2008	ALL	Body	Disc Player and Video Display																																																										
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																									
U	2008	ALL	Body	Left Power Sliding Door Module																																																										
U	2008	ALL	Body	Radio																																																										
U	2008	ALL	Body	Navigation Radio																																																										
U	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
U	2008	ALL	Body	Right Power Sliding Door Module																																																										
U	2009	ALL	Powertrain	Engine Control Module																																																										
U	2009	ALL	Powertrain	Transmission Control Module																																																										
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																										
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																										
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																										
U	2009	ALL	Body	Body Control Module																																																										
U	2009	ALL	Body	Digital Radio Receiver																																																										
U	2009	ALL	Body	Disc Player and Video Display																																																										
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																																										
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																										
U	2009	ALL	Body	Instrument Panel Cluster																																																										
U	2009	ALL	Body	Left Power Sliding Door Module																																																										
U	2009	ALL	Body	Radio																																																										
U	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
U	2009	ALL	Body	Right Power Sliding Door Module																																																										
V	2004	ALL	Powertrain	Engine Data Display																																																										
V	2004	ALL	Powertrain	Transmission Data Display																																																										
V	2004	ALL	Body	Digital Radio Receiver																																																										
V	2004	ALL	Body	Driver Information Center																																																										
V	2004	ALL	Body	Instrument Panel Cluster																																																										
V	2004	ALL	Body	Radio																																																										
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2004	ALL	Body	Vehicle Theft Deterrent																																																										
V	2005	Venture	Powertrain	Engine Control Module																																																										
V	2005	Venture	Powertrain	Transmission Control Module																																																										
V	2005	Venture	Body	Digital Radio Receiver																																																										
V	2005	Venture	Body	Driver Information Center																																																										
V	2005	Venture	Body	Instrument Panel Cluster																																																										
V	2005	Venture	Body	Radio																																																										
V	2005	Venture	Body	Supplemental Inflatable Restraint																																																										
V	2005	Venture	Body	Vehicle Theft Deterrent																																																										
V	2005	Uplander	Powertrain	Engine Control Module																																																										
V	2005	Uplander	Powertrain	Transmission Control Module																																																										
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																										
V	2005	Uplander	Body	Body Control Module																																																										
V	2005	Uplander	Body	Disc Player and Video																																																										
V	2005	Uplander	Body	Digital Radio Receiver																																																										
V	2005	Uplander	Body	HVAC Control Module																																																										
V	2005	Uplander	Body	Instrument Panel Cluster																																																										
V	2005	Uplander	Body	Left Power Sliding Door Module																																																										
V	2005	Uplander	Body	Mobile Digital Media																																																										
V	2005	Uplander	Body	Navigation Radio																																																										
V	2005	Uplander	Body	Navigation Radio																																																										
V	2005	Uplander	Body	Radio																																																										
V	2005	Uplander	Body	Right Power Sliding Door Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
V	2005	Uplander	Body	Supplemental Inflatable Restraint																																																								
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																								
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																								
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																								
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																								
V	2006	ALL	Chassis	Electronic Brake Control Module																																																								
V	2006	ALL	Body	Body Control Module																																																								
V	2006	ALL	Body	Disc Player and Video																																																								
V	2006	ALL	Body	Digital Radio Receiver																																																								
V	2006	ALL	Body	HVAC Control Module																																																								
V	2006	ALL	Body	Instrument Panel Cluster																																																								
V	2006	ALL	Body	Left Power Sliding Door Module																																																								
V	2006	ALL	Body	Mobile Digital Media																																																								
V	2006	ALL	Body	Navigation Radio																																																								
V	2006	ALL	Body	Navigation Radio																																																								
V	2006	ALL	Body	Radio																																																								
V	2006	ALL	Body	Right Power Sliding Door Module																																																								
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																								
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																								
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
V	2007	ALL	Chassis	Electronic Brake Control Module																																																								
V	2007	ALL	Body	Body Control Module																																																								
V	2007	ALL	Body	Digital Radio Receiver																																																								
V	2007	ALL	Body	Disc Player and Video Display																																																								
V	2007	ALL	Body	HVAC Control Module																																																								
V	2007	ALL	Body	Left Power Sliding Door Module																																																								
V	2007	ALL	Body	Mobile Digital Media																																																								
V	2007	ALL	Body	Radio																																																								
V	2007	ALL	Body	Navigation Radio																																																								
V	2007	ALL	Body	Right Power Sliding Door Module																																																								
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																								
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																								
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
V	2008	ALL	Chassis	Electronic Brake Control Module																																																								
V	2008	ALL	Body	Body Control Module																																																								
V	2008	ALL	Body	Digital Radio Receiver																																																								
V	2008	ALL	Body	Disc Player and Video Display																																																								
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																																								
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																								
V	2008	ALL	Body	Left Power Sliding Door Module																																																								
V	2008	ALL	Body	Radio																																																								
V	2008	ALL	Body	Navigation Radio																																																								
V	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
V	2008	ALL	Body	Right Power Sliding Door Module																																																								
V	2009	ALL	Powertrain	Engine Control Module																																																								
V	2009	ALL	Powertrain	Transmission Control Module																																																								
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																								
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																								
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
V	2009	ALL	Body	Body Control Module																																																									
V	2009	ALL	Body	Digital Radio Receiver																																																									
V	2009	ALL	Body	Disc Player and Video Display																																																									
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																																									
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																									
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																									
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																									
V	2009	ALL	Body	Left Power Sliding Door Module																																																									
V	2009	ALL	Body	Radio																																																									
V	2009	ALL	Body	Remote Control Door Lock Receiver																																																									
V	2009	ALL	Body	Right Power Sliding Door Module																																																									
X	2004	ALL	Powertrain	Engine Control Module																																																									
X	2004	ALL	Powertrain	Transmission Control Module																																																									
X	2004	ALL	Body	Digital Radio Receiver																																																									
X	2004	ALL	Body	Driver Information Center																																																									
X	2004	ALL	Body	Instrument Panel Cluster																																																									
X	2004	ALL	Body	Radio																																																									
X	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
X	2004	ALL	Body	Vehicle Theft Deterrent																																																									
X	2005	ALL	Powertrain	Engine Control Module																																																									
X	2005	ALL	Powertrain	Transmission Control Module																																																									
X	2005	ALL	Chassis	Electronic Brake Control Module																																																									
X	2005	ALL	Body	Body Control Module																																																									
X	2005	ALL	Body	Disc Player and Video																																																									
X	2005	ALL	Body	Digital Radio Receiver																																																									
X	2005	ALL	Body	HVAC Control Module																																																									
X	2005	ALL	Body	Instrument Panel Cluster																																																									
X	2005	ALL	Body	Left Power Sliding Door Module																																																									
X	2005	ALL	Body	Mobile Digital Media																																																									
X	2005	ALL	Body	Navigation Radio																																																									
X	2005	ALL	Body	Navigation Radio																																																									
X	2005	ALL	Body	Radio																																																									
X	2005	ALL	Body	Right Power Sliding Door Module																																																									
X	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																									
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																									
X	2006	ALL	Chassis	Electronic Brake Control Module																																																									
X	2006	ALL	Body	Body Control Module																																																									
X	2006	ALL	Body	Disc Player and Video																																																									
X	2006	ALL	Body	Digital Radio Receiver																																																									
X	2006	ALL	Body	HVAC Control Module																																																									
X	2006	ALL	Body	Instrument Panel Cluster																																																									
X	2006	ALL	Body	Left Power Sliding Door Module																																																									
X	2006	ALL	Body	Mobile Digital Media																																																									
X	2006	ALL	Body	Navigation Radio																																																									
X	2006	ALL	Body	Navigation Radio																																																									
X	2006	ALL	Body	Radio																																																									
X	2006	ALL	Body	Right Power Sliding Door Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																											
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																											
A	2006	ALL	Powertrain	Transmission Control Module																																																											
A	2006	ALL	Chassis	Electronic Brake Control Module																																																											
A	2006	ALL	Chassis	Power Steering Control Module																																																											
A	2006	ALL	Body	Body Control Module																																																										
A	2006	ALL	Body	Digital Radio Receiver																																																										
A	2006	ALL	Body	Instrument Panel Cluster																																																										
A	2006	ALL	Body	Radio																																																										
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2006	ALL	Body	Theft Deterrent Module																																																										
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																											
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																											
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																											
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																											
A	2007	ALL	Chassis	Electronic Brake Control Module																																																											
A	2007	ALL	Chassis	Power Steering Control Module																																																											
A	2007	ALL	Body	Body Control Module																																																										
A	2007	ALL	Body	Digital Radio Receiver																																																										
A	2007	ALL	Body	Instrument Panel Cluster																																																										
A	2007	ALL	Body	Radio																																																										
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
A	2007	ALL	Body	Theft Deterrent Module																																																										
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																											
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																											
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																											
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																											
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																											
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																											
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES																																																											
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2008	HHR	Chassis	Power Steering Control Module																																																											
A	2008	HHR	Chassis	Power Steering Control Module																																																											
A	2008	HHR	Body	Body Control Module																																																										
A	2008	HHR	Body	Digital Radio Receiver																																																										
A	2008	HHR	Body	Instrument Panel Cluster																																																										
A	2008	HHR	Body	Radio																																																										
A	2008	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2008	HHR	Body	Theft Deterrent Module																																																										
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																											
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																											
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																											
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																											
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																											
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																											
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																											
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2008	HHR Panel	Body	Body Control Module																																																											
A	2008	HHR Panel	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2008	HHR Panel	Body	Radio																																																										
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2008	HHR Panel	Body	Theft Deterrent Module																																																										
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																																										
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2009	HHR	Chassis	Power Steering Control Module																																																										
A	2009	HHR	Chassis	Power Steering Control Module																																																										
A	2009	HHR	Body	Body Control Module																																																										
A	2009	HHR	Body	Digital Radio Receiver																																																										
A	2009	HHR	Body	Instrument Panel Cluster																																																										
A	2009	HHR	Body	Radio																																																										
A	2009	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2009	HHR	Body	Theft Deterrent Module																																																										
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2009	HHR Panel	Body	Body Control Module																																																										
A	2009	HHR Panel	Body	Digital Radio Receiver																																																										
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2009	HHR Panel	Body	Radio																																																										
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2009	HHR Panel	Body	Theft Deterrent Module																																																										
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																										
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2010	HHR	Chassis	Power Steering Control Module																																																										
A	2010	HHR	Chassis	Power Steering Control Module																																																										
A	2010	HHR	Body	Body Control Module																																																										
A	2010	HHR	Body	Digital Radio Receiver																																																										
A	2010	HHR	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2010	HHR	Body	Radio																																																									
A	2010	HHR	Body	Supplemental Inflatable Restraint																																																									
A	2010	HHR	Body	Theft Deterrent Module																																																									
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																									
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																									
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																									
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																									
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																									
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																									
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																									
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																									
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																									
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																									
A	2010	HHR Panel	Body	Body Control Module																																																									
A	2010	HHR Panel	Body	Digital Radio Receiver																																																									
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																									
A	2010	HHR Panel	Body	Radio																																																									
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																																									
A	2010	HHR Panel	Body	Theft Deterrent Module																																																									
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																									
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																									
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																									
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																									
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																																									
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																																									
A	2011	HHR	Chassis	Power Steering Control Module																																																									
A	2011	HHR	Body	Body Control Module																																																									
A	2011	HHR	Body	Digital Radio Receiver																																																									
A	2011	HHR	Body	Instrument Panel Cluster																																																									
A	2011	HHR	Body	Radio																																																									
A	2011	HHR	Body	Supplemental Inflatable Restraint																																																									
A	2011	HHR	Body	Theft Deterrent Module																																																									
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																									
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																									
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																									
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																									
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																									
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																									
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																									
A	2011	HHR Panel	Body	Body Control Module																																																									
A	2011	HHR Panel	Body	Digital Radio Receiver																																																									
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																									
A	2011	HHR Panel	Body	Radio																																																									
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																																									
A	2011	HHR Panel	Body	Theft Deterrent Module																																																									
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																									
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																									
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
A	2013	Trax	Chassis	Electronic Brake Control Module																																																										
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Trax	Chassis	Power Steering Control Module																																																										
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	Trax	Body	Body Control Module																																																									
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	Trax	Body	Passenger Presence Module																																																										
A	2013	Trax	Body	Instrument Cluster																																																									
A	2013	Trax	Body	Radio																																																									
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
A	2013	Trax	Body	Front Seat Heating Control Module																																																										
A	2013	Trax	Body	Parking Assist Control Module																																																										
A	2013	Trax	Body	Frontview Camera Module																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																													
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																													
A	2014	Trax	Chassis	Electronic Brake Control Module																																																													
A	2014	Trax	Chassis	Power Steering Control Module																																																													
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2014	Trax	Body	Body Control Module																																																													
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2014	Trax	Body	Passenger Presence Module																																																													
A	2014	Trax	Body	Instrument Cluster																																																													
A	2014	Trax	Body	Radio																																																												
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
A	2014	Trax	Body	Front Seat Heating Control Module																																																												
A	2014	Trax	Body	Parking Assist Control Module																																																												
A	2014	Trax	Body	Frontview Camera Module																																																												
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																												
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																												
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																												
A	2015	Trax	Powertrain	Chassis Control Module																																																												
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
A	2015	Trax	Chassis	Electronic Brake Control Module																																																												
A	2015	Trax	Chassis	Power Steering Control Module																																																												
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2015	Trax	Body	Body Control Module																																																												
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2015	Trax	Body	Passenger Presence Module																																																												
A	2015	Trax	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2015	Trax	Body	Radio																																																											
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																												
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
A	2015	Trax	Body	Seat Memory Control Module																																																												
A	2015	Trax	Body	Front Seat Heating Control Module																																																												
A	2015	Trax	Body	Right Side Object Detection Control Module																																																												
A	2015	Trax	Body	Left Side Object Detection Control Module																																																												
A	2015	Trax	Body	Parking Assist Control Module																																																												
A	2015	Trax	Body	Frontview Camera Module																																																												
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																												
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																												
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																												
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																												
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																												
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																												
A	2016	Trax	Powertrain	Chassis Control Module																																																												
A	2016	Trax	Chassis	Electronic Brake Control Module																																																												
A	2016	Trax	Chassis	Power Steering Control Module																																																												
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2016	Trax	Body	Body Control Module																																																												
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2016	Trax	Body	Passenger Presence Module																																																												
A	2016	Trax	Body	Instrument Cluster																																																												
A	2016	Trax	Body	Trailer Interface Control Module																																																												
A	2016	Trax	Body	Radio																																																												
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																												
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
A	2016	Trax	Body	Seat Memory Control Module																																																												
A	2016	Trax	Body	Front Seat Heating Control Module																																																												
A	2016	Trax	Body	Right Side Object Detection Control Module																																																												
A	2016	Trax	Body	Left Side Object Detection Control Module																																																												
A	2016	Trax	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2016	Trax	Body	Frontview Camera Module																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																											
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																											
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																											
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																											
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																											
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
C	2004	ALL	Chassis	ESC																																																										
C	2004	ALL	Chassis	Rear Wheel Steering																																																											
C	2004	ALL	Chassis	Tire Pressure Monitor																																																											
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2004	ALL	Chassis	VSES																																																										
C	2004	ALL	Body	Amplifier (Bose)																																																											
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2004	ALL	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2004	ALL	Body	OnStar																																																								
C	2004	ALL	Body	Passenger Door Module																																																								
C	2004	ALL	Body	Passenger Presence System																																																								
C	2004	ALL	Body	Radio Base																																																								
C	2004	ALL	Body	Radio Uplevel																																																								
C	2004	ALL	Body	Radio Navigation																																																								
C	2004	ALL	Body	Rear Aux. Climate Module																																																								
C	2004	ALL	Body	Rear HVAC																																																								
C	2004	ALL	Body	Rear Seat Audio																																																							V		
C	2004	ALL	Body	Rear Seat Entertainment																																																								
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2004	ALL	Body	Vehicle Theft Deterrent																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																								
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																								
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																								
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																								
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																								
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
C	2005	ALL	Chassis	ESC																																																								
C	2005	ALL	Chassis	Rear Wheel Steering																																																								
C	2005	ALL	Chassis	Tire Pressure Monitor																																																								
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2005	ALL	Chassis	VSES																																																									
C	2005	ALL	Body	Amplifier (Bose)																																																									
C	2005	ALL	Body	Body Control Module																																																									
C	2005	ALL	Body	CD Changer																																																									
C	2005	ALL	Body	Chime																																																									
C	2005	ALL	Body	Disc Player and Video Display																																																									
C	2005	ALL	Body	Driver Door Module																																																									
C	2005	ALL	Body	Driver Seat Module																																																									
C	2005	ALL	Body	Generator Battery Control Module																																																									
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																									
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																									
C	2005	ALL	Body	Instrument Panel Cluster																																																									
C	2005	ALL	Body	Passenger Door Module																																																									
C	2005	ALL	Body	Passenger Presence System																																																									
C	2005	ALL	Body	Base Radio																																																									
C	2005	ALL	Body	Uplevel Radio																																																									
C	2005	ALL	Body	Navigation Radio																																																									
C	2005	ALL	Body	Rear Aux. Climate Module																																																									
C	2005	ALL	Body	Rear HVAC																																																									
C	2005	ALL	Body	Rear Seat Audio																																																						V			
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																									
C	2005	ALL	Body	Vehicle Theft Deterrent																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																									
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																									
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																									
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																								V			
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																											
C	2007	Avalanche	Body	Amplifier (Bose)																																																												
C	2007	Avalanche	Body	Assist Step Controller																																																												
C	2007	Avalanche	Body	Body Control Module																																																												
C	2007	Avalanche	Body	Body Control Module (aux.)																																																												
C	2007	Avalanche	Body	Digital Radio Receiver																																																												
C	2007	Avalanche	Body	Driver Door Switch																																																												
C	2007	Avalanche	Body	HVAC Control Module Auto																																																												
C	2007	Avalanche	Body	HVAC Control Module Manual																																																												
C	2007	Avalanche	Body	Instrument Panel Cluster																																																												
C	2007	Avalanche	Body	Memory Seat Module																																																												
C	2007	Avalanche	Body	Park Assist Module																																																												
C	2007	Avalanche	Body	Passenger Door Switch																																																												
C	2007	Avalanche	Body	Passenger Presence System																																																												
C	2007	Avalanche	Body	Radio																																																												
C	2007	Avalanche	Body	Rear Heated Seat Module																																																												
C	2007	Avalanche	Body	Rear HVAC/RSA																																																												
C	2007	Avalanche	Body	Rollover Sensor																																																												
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																												
C	2007	Avalanche	Body	Theft Deterrent Module																																																												
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Suburban	Chassis	Electronic Suspension Control																																																												
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																												
C	2007	Suburban	Body	Amplifier (Bose)																																																												
C	2007	Suburban	Body	Assist Step Controller																																																												
C	2007	Suburban	Body	Body Control Module																																																												
C	2007	Suburban	Body	Body Control Module (aux.)																																																												
C	2007	Suburban	Body	Digital Radio Receiver																																																												
C	2007	Suburban	Body	Driver Door Switch																																																												
C	2007	Suburban	Body	HVAC Control Module Auto																																																												
C	2007	Suburban	Body	HVAC Control Module Manual																																																												
C	2007	Suburban	Body	Instrument Panel Cluster																																																												
C	2007	Suburban	Body	Lift Gate Module																																																												
C	2007	Suburban	Body	Memory Seat Module																																																												
C	2007	Suburban	Body	Park Assist Module																																																												
C	2007	Suburban	Body	Passenger Door Switch																																																												
C	2007	Suburban	Body	Passenger Presence System																																																												
C	2007	Suburban	Body	Radio																																																											
C	2007	Suburban	Body	Rear Heated Seat Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2007	Suburban	Body	Rear HVAC/RSA																																																											
C	2007	Suburban	Body	Rollover Sensor																																																											
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																																											
C	2007	Suburban	Body	Theft Deterrent Module																																																											
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2007	Silverado	Chassis	Electronic Suspension Control																																																											
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																											
C	2007	Silverado	Body	Amplifier (Bose)																																																											
C	2007	Silverado	Body	Body Control Module																																																											
C	2007	Silverado	Body	Body Control Module (aux.)																																																											
C	2007	Silverado	Body	Digital Radio Receiver																																																											
C	2007	Silverado	Body	Driver Door Switch																																																											
C	2007	Silverado	Body	HVAC Control Module Auto																																																											
C	2007	Silverado	Body	HVAC Control Module Manual																																																											
C	2007	Silverado	Body	Instrument Panel Cluster																																																											
C	2007	Silverado	Body	Memory Seat Module																																																											
C	2007	Silverado	Body	Park Assist Module																																																											
C	2007	Silverado	Body	Passenger Door Switch																																																											
C	2007	Silverado	Body	Passenger Presence System																																																											
C	2007	Silverado	Body	Radio																																																											
C	2007	Silverado	Body	Rear Heated Seat Module																																																											
C	2007	Silverado	Body	Rear HVAC/RSA																																																											
C	2007	Silverado	Body	Rollover Sensor																																																											
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2007	Silverado	Body	Theft Deterrent Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2007	Tahoe	Body	Amplifier (Bose)																																																										
C	2007	Tahoe	Body	Assist Step Controller																																																										
C	2007	Tahoe	Body	Body Control Module																																																										
C	2007	Tahoe	Body	Body Control Module (aux.)																																																										
C	2007	Tahoe	Body	Digital Radio Receiver																																																										
C	2007	Tahoe	Body	Driver Door Switch																																																										
C	2007	Tahoe	Body	HVAC Control Module Auto																																																										
C	2007	Tahoe	Body	HVAC Control Module Manual																																																										
C	2007	Tahoe	Body	Instrument Panel Cluster																																																										
C	2007	Tahoe	Body	Lift Gate Module																																																										
C	2007	Tahoe	Body	Memory Seat Module																																																										
C	2007	Tahoe	Body	Park Assist Module																																																										
C	2007	Tahoe	Body	Passenger Door Switch																																																										
C	2007	Tahoe	Body	Passenger Presence System																																																										
C	2007	Tahoe	Body	Radio																																																										
C	2007	Tahoe	Body	Rear Heated Seat Module																																																										
C	2007	Tahoe	Body	Rear HVAC/RSA																																																										
C	2007	Tahoe	Body	Rollover Sensor																																																										
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2007	Tahoe	Body	Theft Deterrent Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2008	Avalanche	Body	Amplifier (Bose)																																																										
C	2008	Avalanche	Body	Assist Step Controller																																																										
C	2008	Avalanche	Body	Body Control Module																																																										
C	2008	Avalanche	Body	Body Control Module (aux.)																																																										
C	2008	Avalanche	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2008	Avalanche	Body	Driver Door Switch																																																											
C	2008	Avalanche	Body	HVAC Control Module Auto																																																											
C	2008	Avalanche	Body	HVAC Control Module Manual																																																											
C	2008	Avalanche	Body	Instrument Panel Cluster																																																											
C	2008	Avalanche	Body	Memory Seat Module																																																											
C	2008	Avalanche	Body	Park Assist Module																																																											
C	2008	Avalanche	Body	Passenger Door Switch																																																											
C	2008	Avalanche	Body	Passenger Presence System																																																											
C	2008	Avalanche	Body	Radio																																																											
C	2008	Avalanche	Body	Rear Heated Seat Module																																																											
C	2008	Avalanche	Body	Rear HVAC/RSA																																																											
C	2008	Avalanche	Body	Rollover Sensor																																																											
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																											
C	2008	Avalanche	Body	Theft Deterrent Module																																																											
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2008	Suburban	Chassis	Electronic Suspension Control																																																											
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																											
C	2008	Suburban	Body	Amplifier (Bose)																																																											
C	2008	Suburban	Body	Assist Step Controller																																																											
C	2008	Suburban	Body	Body Control Module																																																											
C	2008	Suburban	Body	Body Control Module (aux.)																																																											
C	2008	Suburban	Body	Digital Radio Receiver																																																											
C	2008	Suburban	Body	Driver Door Switch																																																											
C	2008	Suburban	Body	HVAC Control Module Auto																																																											
C	2008	Suburban	Body	HVAC Control Module Manual																																																											
C	2008	Suburban	Body	Instrument Panel Cluster																																																											
C	2008	Suburban	Body	Lift Gate Module																																																											
C	2008	Suburban	Body	Memory Seat Module																																																											
C	2008	Suburban	Body	Park Assist Module																																																											
C	2008	Suburban	Body	Passenger Door Switch																																																											
C	2008	Suburban	Body	Passenger Presence System																																																											
C	2008	Suburban	Body	Radio																																																											
C	2008	Suburban	Body	Rear Heated Seat Module																																																											
C	2008	Suburban	Body	Rear HVAC/RSA																																																											
C	2008	Suburban	Body	Rollover Sensor																																																											
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2008	Suburban	Body	Theft Deterrent Module																																																											
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Silverado	Chassis	Electronic Suspension Control																																																												
C	2008	Silverado	Chassis	Trailer Brake Control Module																																																												
C	2008	Silverado	Body	Amplifier (Bose)																																																												
C	2008	Silverado	Body	Body Control Module																																																												
C	2008	Silverado	Body	Body Control Module (aux.)																																																												
C	2008	Silverado	Body	Digital Radio Receiver																																																												
C	2008	Silverado	Body	Driver Door Switch																																																												
C	2008	Silverado	Body	HVAC Control Module Auto																																																												
C	2008	Silverado	Body	HVAC Control Module Manual																																																												
C	2008	Silverado	Body	Instrument Panel Cluster																																																												
C	2008	Silverado	Body	Memory Seat Module																																																												
C	2008	Silverado	Body	Park Assist Module																																																												
C	2008	Silverado	Body	Passenger Door Switch																																																												
C	2008	Silverado	Body	Passenger Presence System																																																												
C	2008	Silverado	Body	Radio																																																											
C	2008	Silverado	Body	Rear Heated Seat Module																																																												
C	2008	Silverado	Body	Rear HVAC/RSA																																																												
C	2008	Silverado	Body	Rollover Sensor																																																												
C	2008	Silverado	Body	Supplemental Inflatable Restraint																																																												
C	2008	Silverado	Body	Theft Deterrent Module																																																												
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																																												
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																												
C	2008	Tahoe	Body	Amplifier (Bose)																																																												
C	2008	Tahoe	Body	Assist Step Controller																																																												
C	2008	Tahoe	Body	Body Control Module																																																												
C	2008	Tahoe	Body	Body Control Module (aux.)																																																												
C	2008	Tahoe	Body	Digital Radio Receiver																																																												
C	2008	Tahoe	Body	Driver Door Switch																																																												
C	2008	Tahoe	Body	HVAC Control Module Auto																																																												
C	2008	Tahoe	Body	HVAC Control Module Manual																																																												
C	2008	Tahoe	Body	Instrument Panel Cluster																																																												
C	2008	Tahoe	Body	Memory Seat Module																																																												
C	2008	Tahoe	Body	Park Assist Module																																																												
C	2008	Tahoe	Body	Passenger Presence System																																																												
C	2008	Tahoe	Body	Radio																																																												
C	2008	Tahoe	Body	Rear Heated Seat Module																																																												
C	2008	Tahoe	Body	Rear HVAC/RSA																																																												
C	2008	Tahoe	Body	Rollover Sensor																																																												
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2008	Tahoe	Body	Theft Deterrent Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2008	Tahoe Hybrid	Body	Body Control Module																																																												
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2008	Tahoe Hybrid	Body	HVAC Control Module																																																												
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2008	Tahoe Hybrid	Body	Memory Seat Module																																																												
C	2008	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2008	Tahoe Hybrid	Body	Radio																																																										
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																																										
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2009	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2009	Avalanche	Chassis	Trailer Brake Control Module																																																										
C	2009	Avalanche	Body	Amplifier (Bose)																																																										
C	2009	Avalanche	Body	Assist Step Controller																																																										
C	2009	Avalanche	Body	Body Control Module																																																										
C	2009	Avalanche	Body	Body Control Module (aux.)																																																										
C	2009	Avalanche	Body	Digital Radio Receiver																																																										
C	2009	Avalanche	Body	Driver Door Switch																																																										
C	2009	Avalanche	Body	HVAC Control Module Auto																																																										
C	2009	Avalanche	Body	HVAC Control Module Manual																																																										
C	2009	Avalanche	Body	Instrument Panel Cluster																																																										
C	2009	Avalanche	Body	Memory Seat Module																																																										
C	2009	Avalanche	Body	Park Assist Module																																																										
C	2009	Avalanche	Body	Passenger Door Switch																																																										
C	2009	Avalanche	Body	Passenger Presence System																																																										
C	2009	Avalanche	Body	Radio																																																										
C	2009	Avalanche	Body	Rear Heated Seat Module																																																										
C	2009	Avalanche	Body	Rear HVAC/RSA																																																										
C	2009	Avalanche	Body	Rollover Sensor																																																										
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2009	Avalanche	Body	Theft Deterrent Module																																																										
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																												
C	2009	Cheyenne	Body	Amplifier (Bose)																																																												
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																												
C	2009	Cheyenne	Body	Digital Radio Receiver																																																												
C	2009	Cheyenne	Body	Driver Door Switch																																																												
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																												
C	2009	Cheyenne	Body	Park Assist Module																																																												
C	2009	Cheyenne	Body	Passenger Door Switch																																																												
C	2009	Cheyenne	Body	Passenger Presence System																																																												
C	2009	Cheyenne	Body	Rear Heated Seat Module																																																												
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																												
C	2009	Cheyenne	Body	Rollover Sensor																																																												
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																												
C	2009	Cheyenne	Body	Theft Deterrent Module																																																												
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																												
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2009	Suburban	Chassis	Electronic Suspension Control																																																												
C	2009	Suburban	Chassis	Trailer Brake Control Module																																																												
C	2009	Suburban	Body	Amplifier (Bose)																																																												
C	2009	Suburban	Body	Assist Step Controller																																																												
C	2009	Suburban	Body	Body Control Module																																																												
C	2009	Suburban	Body	Body Control Module (aux.)																																																												
C	2009	Suburban	Body	Digital Radio Receiver																																																												
C	2009	Suburban	Body	Driver Door Switch																																																												
C	2009	Suburban	Body	HVAC Control Module Auto																																																												
C	2009	Suburban	Body	HVAC Control Module Manual																																																												
C	2009	Suburban	Body	Instrument Panel Cluster																																																												
C	2009	Suburban	Body	Left Side Object Detection Module																																																												
C	2009	Suburban	Body	Lift Gate Module																																																												
C	2009	Suburban	Body	Memory Seat Module																																																												
C	2009	Suburban	Body	Park Assist Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2009	Suburban	Body	Passenger Door Switch																																																											
C	2009	Suburban	Body	Passenger Presence System																																																												
C	2009	Suburban	Body	Radio																																																											
C	2009	Suburban	Body	Rear Heated Seat Module																																																											
C	2009	Suburban	Body	Rear HVAC/RSA																																																											
C	2009	Suburban	Body	Right Side Object Detection Module																																																											
C	2009	Suburban	Body	Rollover Sensor																																																											
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																																											
C	2009	Suburban	Body	Theft Deterrent Module																																																											
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																											
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																											
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																											
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																											
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																											
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2009	Silverado	Chassis	Electronic Suspension Control																																																											
C	2009	Silverado	Chassis	Trailer Brake Control Module																																																											
C	2009	Silverado	Body	Amplifier (Bose)																																																											
C	2009	Silverado	Body	Body Control Module																																																											
C	2009	Silverado	Body	Body Control Module (aux.)																																																											
C	2009	Silverado	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2009	Silverado	Body	Driver Door Switch																																																											
C	2009	Silverado	Body	HVAC Control Module Auto																																																												
C	2009	Silverado	Body	HVAC Control Module Manual																																																												
C	2009	Silverado	Body	Instrument Panel Cluster																																																												
C	2009	Silverado	Body	Memory Seat Module																																																												
C	2009	Silverado	Body	Park Assist Module																																																												
C	2009	Silverado	Body	Passenger Door Switch																																																												
C	2009	Silverado	Body	Passenger Presence System																																																												
C	2009	Silverado	Body	Radio																																																												
C	2009	Silverado	Body	Rear Heated Seat Module																																																												
C	2009	Silverado	Body	Rear HVAC/RSA																																																												
C	2009	Silverado	Body	Rollover Sensor																																																												
C	2009	Silverado	Body	Supplemental Inflatable Restraint																																																												
C	2009	Silverado	Body	Theft Deterrent Module																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																												
C	2009	Silverado Hybrid	Body	Body Control Module																																																												
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																												
C	2009	Silverado Hybrid	Body	Driver Door Switch																																																												
C	2009	Silverado Hybrid	Body	HVAC Control Module																																																												
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
C	2009	Silverado Hybrid	Body	Memory Seat Module																																																												
C	2009	Silverado Hybrid	Body	Park Assist Module																																																												
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																																												
C	2009	Silverado Hybrid	Body	Passenger Presence System																																																												
C	2009	Silverado Hybrid	Body	Radio																																																												
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
C	2009	Silverado Hybrid	Body	Rollover Sensor																																																												
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																												
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																																												
C	2009	Tahoe	Body	Amplifier (Bose)																																																												
C	2009	Tahoe	Body	Assist Step Controller																																																												
C	2009	Tahoe	Body	Body Control Module																																																												
C	2009	Tahoe	Body	Body Control Module (aux.)																																																												
C	2009	Tahoe	Body	Digital Radio Receiver																																																												
C	2009	Tahoe	Body	Driver Door Switch																																																												
C	2009	Tahoe	Body	HVAC Control Module Auto																																																												
C	2009	Tahoe	Body	HVAC Control Module Manual																																																												
C	2009	Tahoe	Body	Instrument Panel Cluster																																																												
C	2009	Tahoe	Body	Left Side Object Detection Module																																																												
C	2009	Tahoe	Body	Lift Gate Module																																																												
C	2009	Tahoe	Body	Memory Seat Module																																																												
C	2009	Tahoe	Body	Park Assist Module																																																												
C	2009	Tahoe	Body	Passenger Door Switch																																																												
C	2009	Tahoe	Body	Passenger Presence System																																																												
C	2009	Tahoe	Body	Radio																																																											
C	2009	Tahoe	Body	Rear Heated Seat Module																																																												
C	2009	Tahoe	Body	Rear HVAC/RSA																																																												
C	2009	Tahoe	Body	Right Side Object Detection Module																																																												
C	2009	Tahoe	Body	Rollover Sensor																																																												
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2009	Tahoe	Body	Theft Deterrent Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2009	Tahoe Hybrid	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																																											
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																																											
C	2009	Tahoe Hybrid	Body	HVAC Control Module																																																											
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
C	2009	Tahoe Hybrid	Body	Park Assist Module																																																											
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																											
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																																											
C	2009	Tahoe Hybrid	Body	Radio																																																											
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																											
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	Avalanche	Chassis	Electronic Brake Control Module																																																											
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																											
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Avalanche	Body	Amplifier (Bose)																																																											
C	2010	Avalanche	Body	Assist Step Controller																																																											
C	2010	Avalanche	Body	Body Control Module																																																											
C	2010	Avalanche	Body	Body Control Module (aux.)																																																											
C	2010	Avalanche	Body	Digital Radio Receiver																																																											
C	2010	Avalanche	Body	Driver Door Switch																																																											
C	2010	Avalanche	Body	HVAC Control Module Auto																																																											
C	2010	Avalanche	Body	HVAC Control Module Manual																																																											
C	2010	Avalanche	Body	Instrument Panel Cluster																																																											
C	2010	Avalanche	Body	Memory Seat Module																																																											
C	2010	Avalanche	Body	Park Assist Module																																																											
C	2010	Avalanche	Body	Passenger Door Switch																																																											
C	2010	Avalanche	Body	Passenger Presence System																																																											
C	2010	Avalanche	Body	Radio																																																											
C	2010	Avalanche	Body	Rear Heated Seat Module																																																											
C	2010	Avalanche	Body	Rear HVAC/RSA																																																											
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																											
C	2010	Avalanche	Body	Theft Deterrent Module																																																											
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Cheyenne	Body	Amplifier (Bose)																																																										
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2010	Cheyenne	Body	Digital Radio Receiver																																																										
C	2010	Cheyenne	Body	Driver Door Switch																																																										
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2010	Cheyenne	Body	Park Assist Module																																																										
C	2010	Cheyenne	Body	Passenger Door Switch																																																										
C	2010	Cheyenne	Body	Passenger Presence System																																																										
C	2010	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2010	Cheyenne	Body	Theft Deterrent Module																																																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																												V	V	V	V																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2010	Suburban	Chassis	Electronic Suspension Control																																																										
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Suburban	Body	Amplifier (Bose)																																																										
C	2010	Suburban	Body	Assist Step Controller																																																										
C	2010	Suburban	Body	Body Control Module																																																										
C	2010	Suburban	Body	Body Control Module (aux.)																																																										
C	2010	Suburban	Body	Digital Radio Receiver																																																										
C	2010	Suburban	Body	Driver Door Switch																																																										
C	2010	Suburban	Body	HVAC Control Module Auto																																																										
C	2010	Suburban	Body	HVAC Control Module Manual																																																										
C	2010	Suburban	Body	Instrument Panel Cluster																																																										
C	2010	Suburban	Body	Left Side Object Detection Module																																																										
C	2010	Suburban	Body	Lift Gate Module																																																										
C	2010	Suburban	Body	Memory Seat Module																																																										
C	2010	Suburban	Body	Park Assist Module																																																										
C	2010	Suburban	Body	Passenger Door Switch																																																										
C	2010	Suburban	Body	Passenger Presence System																																																										
C	2010	Suburban	Body	Radio																																																										
C	2010	Suburban	Body	Rear Heated Seat Module																																																										
C	2010	Suburban	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2010	Suburban	Body	Right Side Object Detection Module																																																											
C	2010	Suburban	Body	Supplemental Inflatable Restraint																																																											
C	2010	Suburban	Body	Theft Deterrent Module																																																											
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																											
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																											
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2010	Silverado	Chassis	Electronic Suspension Control																																																											
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2010	Silverado	Body	Amplifier (Bose)																																																											
C	2010	Silverado	Body	Body Control Module																																																											
C	2010	Silverado	Body	Body Control Module (aux.)																																																											
C	2010	Silverado	Body	Digital Radio Receiver																																																											
C	2010	Silverado	Body	Driver Door Switch																																																											
C	2010	Silverado	Body	HVAC Control Module Auto																																																											
C	2010	Silverado	Body	HVAC Control Module Manual																																																											
C	2010	Silverado	Body	Instrument Panel Cluster																																																											
C	2010	Silverado	Body	Memory Seat Module																																																											
C	2010	Silverado	Body	Park Assist Module																																																											
C	2010	Silverado	Body	Passenger Door Switch																																																											
C	2010	Silverado	Body	Passenger Presence System																																																											
C	2010	Silverado	Body	Radio																																																											
C	2010	Silverado	Body	Rear Heated Seat Module																																																											
C	2010	Silverado	Body	Rear HVAC/RSA																																																											
C	2010	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2010	Silverado	Body	Theft Deterrent Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																											
C	2010	Silverado Hybrid	Body	Body Control Module																																																											
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																											
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																											
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																											
C	2010	Silverado Hybrid	Body	HVAC Control Module																																																											
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
C	2010	Silverado Hybrid	Body	Park Assist Module																																																											
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2010	Silverado Hybrid	Body	Passenger Presence System																																																											
C	2010	Silverado Hybrid	Body	Radio																																																											
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																												V	V	V	V																											
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Tahoe	Body	Amplifier (Bose)																																																											
C	2010	Tahoe	Body	Assist Step Controller																																																											
C	2010	Tahoe	Body	Body Control Module																																																											
C	2010	Tahoe	Body	Body Control Module (aux.)																																																											
C	2010	Tahoe	Body	Digital Radio Receiver																																																											
C	2010	Tahoe	Body	Driver Door Switch																																																											
C	2010	Tahoe	Body	HVAC Control Module Auto																																																											
C	2010	Tahoe	Body	HVAC Control Module Manual																																																											
C	2010	Tahoe	Body	Instrument Panel Cluster																																																											
C	2010	Tahoe	Body	Left Side Object Detection Module																																																											
C	2010	Tahoe	Body	Lift Gate Module																																																											
C	2010	Tahoe	Body	Memory Seat Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2010	Tahoe	Body	Park Assist Module																																																											
C	2010	Tahoe	Body	Passenger Door Switch																																																												
C	2010	Tahoe	Body	Passenger Presence System																																																												
C	2010	Tahoe	Body	Radio																																																												
C	2010	Tahoe	Body	Rear Heated Seat Module																																																												
C	2010	Tahoe	Body	Rear HVAC/RSA																																																												
C	2010	Tahoe	Body	Right Side Object Detection Module																																																												
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2010	Tahoe	Body	Theft Deterrent Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2010	Tahoe Hybrid	Body	Body Control Module																																																												
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																																												
C	2010	Tahoe Hybrid	Body	HVAC Control Module																																																												
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																																												
C	2010	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																												
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																																												
C	2010	Tahoe Hybrid	Body	Radio																																																												
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2011	Avalanche	Chassis	Electronic Brake Control Module																																																												
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																												
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2011	Avalanche	Body	Amplifier (Bose)																																																											
C	2011	Avalanche	Body	Assist Step Controller																																																												
C	2011	Avalanche	Body	Body Control Module																																																												
C	2011	Avalanche	Body	Body Control Module (aux.)																																																												
C	2011	Avalanche	Body	Digital Radio Receiver																																																												
C	2011	Avalanche	Body	Driver Door Switch																																																												
C	2011	Avalanche	Body	HVAC Control Module Auto																																																												
C	2011	Avalanche	Body	HVAC Control Module Manual																																																												
C	2011	Avalanche	Body	Instrument Panel Cluster																																																												
C	2011	Avalanche	Body	Memory Seat Module																																																												
C	2011	Avalanche	Body	Park Assist Module																																																												
C	2011	Avalanche	Body	Passenger Door Switch																																																												
C	2011	Avalanche	Body	Passenger Presence System																																																												
C	2011	Avalanche	Body	Radio																																																												
C	2011	Avalanche	Body	Rear Heated Seat Module																																																												
C	2011	Avalanche	Body	Rear HVAC/RSA																																																												
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																												
C	2011	Avalanche	Body	Theft Deterrent Module																																																												
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																												
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																												
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																												
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																												
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
C	2011	Captiva	Chassis	Electronic Brake Control Module																																																												
C	2011	Captiva	Chassis	Parking Brake Control Module																																																												
C	2011	Captiva	Body	Body Control Module																																																												
C	2011	Captiva	Body	Auxiliary Body Control Module																																																												
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2011	Captiva	Body	Instrument Cluster																																																												
C	2011	Captiva	Body	Headlamp Control Module																																																												
C	2011	Captiva	Body	HVAC Control Module																																																												
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																												
C	2011	Captiva	Body	Parking Assist Control Module																																																												
C	2011	Captiva	Body	Theft Deterrent Module																																																												
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																									
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																									
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																									
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																									
C	2011	Cheyenne	Body	Amplifier (Bose)																																																									
C	2011	Cheyenne	Body	Body Control Module																																																									
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																									
C	2011	Cheyenne	Body	Digital Radio Receiver																																																									
C	2011	Cheyenne	Body	Driver Door Switch																																																									
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																									
C	2011	Cheyenne	Body	Park Assist Module																																																									
C	2011	Cheyenne	Body	Passenger Door Switch																																																									
C	2011	Cheyenne	Body	Passenger Presence System																																																									
C	2011	Cheyenne	Body	Rear Heated Seat Module																																																									
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																									
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																									
C	2011	Cheyenne	Body	Theft Deterrent Module																																																									
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																												V	V	V	V																										
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																									
C	2011	Suburban	Chassis	Electronic Suspension Control																																																									
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2011	Suburban	Body	Amplifier (Bose)																																																									
C	2011	Suburban	Body	Assist Step Controller																																																									
C	2011	Suburban	Body	Body Control Module																																																									
C	2011	Suburban	Body	Body Control Module (aux.)																																																									
C	2011	Suburban	Body	Digital Radio Receiver																																																									
C	2011	Suburban	Body	Driver Door Switch																																																									
C	2011	Suburban	Body	HVAC Control Module Auto																																																									
C	2011	Suburban	Body	HVAC Control Module Manual																																																									
C	2011	Suburban	Body	Instrument Panel Cluster																																																									
C	2011	Suburban	Body	Left Side Object Detection Module																																																									
C	2011	Suburban	Body	Lift Gate Module																																																									
C	2011	Suburban	Body	Memory Seat Module																																																									
C	2011	Suburban	Body	Park Assist Module																																																									
C	2011	Suburban	Body	Passenger Door Switch																																																									
C	2011	Suburban	Body	Passenger Presence System																																																									
C	2011	Suburban	Body	Radio																																																									
C	2011	Suburban	Body	Rear Heated Seat Module																																																									
C	2011	Suburban	Body	Rear HVAC/RSA																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2011	Suburban	Body	Right Side Object Detection Module																																																											
C	2011	Suburban	Body	Supplemental Inflatable Restraint																																																											
C	2011	Suburban	Body	Theft Deterrent Module																																																											
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																							V																																				
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																											
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V	V	V																																																						
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																											
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																						
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																											
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2011	Silverado	Chassis	Electronic Suspension Control																																																											
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2011	Silverado	Body	Amplifier (Bose)																																																											
C	2011	Silverado	Body	Body Control Module																																																										
C	2011	Silverado	Body	Body Control Module (aux.)																																																										
C	2011	Silverado	Body	Digital Radio Receiver																																																										
C	2011	Silverado	Body	Driver Door Switch																																																										
C	2011	Silverado	Body	HVAC Control Module Auto																																																										
C	2011	Silverado	Body	HVAC Control Module Manual																																																										
C	2011	Silverado	Body	Instrument Panel Cluster																																																										
C	2011	Silverado	Body	Memory Seat Module																																																										
C	2011	Silverado	Body	Park Assist Module																																																										
C	2011	Silverado	Body	Passenger Door Switch																																																										
C	2011	Silverado	Body	Passenger Presence System																																																										
C	2011	Silverado	Body	Radio																																																										
C	2011	Silverado	Body	Rear Heated Seat Module																																																										
C	2011	Silverado	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2011	Silverado	Body	Theft Deterrent Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Silverado Hybrid	Body	Body Control Module																																																										
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2011	Silverado Hybrid	Body	HVAC Control Module																																																										
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Silverado Hybrid	Body	Park Assist Module																																																										
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2011	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2011	Silverado Hybrid	Body	Radio																																																										
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																													V	V	V	V																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe	Body	Amplifier (Bose)																																																										
C	2011	Tahoe	Body	Assist Step Controller																																																										
C	2011	Tahoe	Body	Body Control Module																																																										
C	2011	Tahoe	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe	Body	Digital Radio Receiver																																																										
C	2011	Tahoe	Body	Driver Door Switch																																																										
C	2011	Tahoe	Body	HVAC Control Module Auto																																																										
C	2011	Tahoe	Body	HVAC Control Module Manual																																																										
C	2011	Tahoe	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe	Body	Left Side Object Detection Module																																																										
C	2011	Tahoe	Body	Lift Gate Module																																																										
C	2011	Tahoe	Body	Memory Seat Module																																																										
C	2011	Tahoe	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2011	Tahoe	Body	Passenger Door Switch																																																										
C	2011	Tahoe	Body	Passenger Presence System																																																										
C	2011	Tahoe	Body	Radio																																																										
C	2011	Tahoe	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe	Body	Right Side Object Detection Module																																																										
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2011	Tahoe	Body	Theft Deterrent Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Tahoe Hybrid	Body	Body Control Module																																																										
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2011	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2011	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2011	Tahoe Hybrid	Body	Radio																																																										
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2012	Avalanche	Body	Amplifier (Bose)																																																											
C	2012	Avalanche	Body	Assist Step Controller																																																												
C	2012	Avalanche	Body	Body Control Module																																																												
C	2012	Avalanche	Body	Body Control Module (aux.)																																																												
C	2012	Avalanche	Body	Digital Radio Receiver																																																												
C	2012	Avalanche	Body	Driver Door Switch																																																												
C	2012	Avalanche	Body	HVAC Control Module Auto																																																												
C	2012	Avalanche	Body	HVAC Control Module Manual																																																												
C	2012	Avalanche	Body	Instrument Panel Cluster																																																												
C	2012	Avalanche	Body	Memory Seat Module																																																												
C	2012	Avalanche	Body	Navigation Radio																																																												
C	2012	Avalanche	Body	Park Assist Module																																																												
C	2012	Avalanche	Body	Passenger Door Switch																																																												
C	2012	Avalanche	Body	Passenger Presence System																																																												
C	2012	Avalanche	Body	Radio																																																											
C	2012	Avalanche	Body	Rear Heated Seat Module																																																												
C	2012	Avalanche	Body	Rear HVAC/RSA																																																												
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																												
C	2012	Avalanche	Body	Theft Deterrent Module																																																												
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																												
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																												
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																												
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																												
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																												
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																												
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																												
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																												
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																												
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																												
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																												
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																												
C	2012	Captiva	Chassis	Parking Brake Control Module																																																												
C	2012	Captiva	Body	Body Control Module																																																												
C	2012	Captiva	Body	Auxiliary Body Control Module																																																												
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2012	Captiva	Body	Instrument Cluster																																																												
C	2012	Captiva	Body	Headlamp Control Module																																																												
C	2012	Captiva	Body	HVAC Control Module																																																												
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																												
C	2012	Captiva	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2012	Captiva	Body	Theft Deterrent Module																																																										
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																										
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Cheyenne	Body	Amplifier (Bose)																																																										
C	2012	Cheyenne	Body	Body Control Module																																																										
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2012	Cheyenne	Body	Digital Radio Receiver																																																										
C	2012	Cheyenne	Body	Driver Door Switch																																																										
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2012	Cheyenne	Body	Park Assist Module																																																										
C	2012	Cheyenne	Body	Passenger Door Switch																																																										
C	2012	Cheyenne	Body	Passenger Presence System																																																										
C	2012	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2012	Cheyenne	Body	Theft Deterrent Module																																																										
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																													V	V	V	V																										
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																										
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2012	Suburban	Chassis	Electronic Suspension Control																																																										
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Suburban	Body	Amplifier (Bose)																																																										
C	2012	Suburban	Body	Assist Step Controller																																																										
C	2012	Suburban	Body	Body Control Module																																																										
C	2012	Suburban	Body	Body Control Module (aux.)																																																										
C	2012	Suburban	Body	Digital Radio Receiver																																																										
C	2012	Suburban	Body	Driver Door Switch																																																										
C	2012	Suburban	Body	HVAC Control Module Auto																																																										
C	2012	Suburban	Body	HVAC Control Module Manual																																																										
C	2012	Suburban	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2012	Suburban	Body	Left Side Object Detection Module																																																											
C	2012	Suburban	Body	Lift Gate Module																																																												
C	2012	Suburban	Body	Memory Seat Module																																																												
C	2012	Suburban	Body	Navigation Radio																																																												
C	2012	Suburban	Body	Park Assist Module																																																												
C	2012	Suburban	Body	Passenger Door Switch																																																												
C	2012	Suburban	Body	Passenger Presence System																																																												
C	2012	Suburban	Body	Radio																																																												
C	2012	Suburban	Body	Rear Heated Seat Module																																																												
C	2012	Suburban	Body	Rear HVAC/RSA																																																												
C	2012	Suburban	Body	Right Side Object Detection Module																																																												
C	2012	Suburban	Body	Supplemental Inflatable Restraint																																																												
C	2012	Suburban	Body	Theft Deterrent Module																																																												
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																							V																																					
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V	V	V																																																						
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																						
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2012	Silverado	Chassis	Electronic Suspension Control																																																												
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2012	Silverado	Body	Amplifier (Bose)																																																												
C	2012	Silverado	Body	Body Control Module																																																												
C	2012	Silverado	Body	Body Control Module (aux.)																																																												
C	2012	Silverado	Body	Digital Radio Receiver																																																												
C	2012	Silverado	Body	Driver Door Switch																																																												
C	2012	Silverado	Body	HVAC Control Module Auto																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2012	Silverado	Body	HVAC Control Module Manual																																																										
C	2012	Silverado	Body	Instrument Panel Cluster																																																											
C	2012	Silverado	Body	Memory Seat Module																																																											
C	2012	Silverado	Body	Navigation Radio																																																											
C	2012	Silverado	Body	Park Assist Module																																																											
C	2012	Silverado	Body	Passenger Door Switch																																																											
C	2012	Silverado	Body	Passenger Presence System																																																											
C	2012	Silverado	Body	Radio																																																											
C	2012	Silverado	Body	Rear Heated Seat Module																																																											
C	2012	Silverado	Body	Rear HVAC/RSA																																																											
C	2012	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2012	Silverado	Body	Theft Deterrent Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																											
C	2012	Silverado Hybrid	Body	Body Control Module																																																											
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																											
C	2012	Silverado Hybrid	Body	Driver Door Switch																																																											
C	2012	Silverado Hybrid	Body	Heated Seat Module																																																											
C	2012	Silverado Hybrid	Body	HVAC Control Module																																																											
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
C	2012	Silverado Hybrid	Body	Navigation Radio																																																											
C	2012	Silverado Hybrid	Body	Park Assist Module																																																											
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2012	Silverado Hybrid	Body	Passenger Presence System																																																											
C	2012	Silverado Hybrid	Body	Radio																																																											
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																												V	V	V	V																											
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2012	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2012	Tahoe	Body	Amplifier (Bose)																																																											
C	2012	Tahoe	Body	Assist Step Controller																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2012	Tahoe	Body	Body Control Module																																																										
C	2012	Tahoe	Body	Body Control Module (aux.)																																																										
C	2012	Tahoe	Body	Digital Radio Receiver																																																										
C	2012	Tahoe	Body	Driver Door Switch																																																										
C	2012	Tahoe	Body	HVAC Control Module Auto																																																										
C	2012	Tahoe	Body	HVAC Control Module Manual																																																										
C	2012	Tahoe	Body	Instrument Panel Cluster																																																										
C	2012	Tahoe	Body	Left Side Object Detection Module																																																										
C	2012	Tahoe	Body	Lift Gate Module																																																										
C	2012	Tahoe	Body	Memory Seat Module																																																										
C	2012	Tahoe	Body	Navigation Radio																																																										
C	2012	Tahoe	Body	Park Assist Module																																																										
C	2012	Tahoe	Body	Passenger Door Switch																																																										
C	2012	Tahoe	Body	Passenger Presence System																																																										
C	2012	Tahoe	Body	Radio																																																										
C	2012	Tahoe	Body	Rear Heated Seat Module																																																										
C	2012	Tahoe	Body	Rear HVAC/RSA																																																										
C	2012	Tahoe	Body	Right Side Object Detection Module																																																										
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2012	Tahoe	Body	Theft Deterrent Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2012	Tahoe Hybrid	Body	Body Control Module																																																										
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2012	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2012	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2012	Tahoe Hybrid	Body	Navigation Radio																																																										
C	2012	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2012	Tahoe Hybrid	Body	Radio																																																										
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2013	Avalanche	Chassis	Electronic Brake Control Module																																																											
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																											
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Avalanche	Body	Amplifier (Bose)																																																											
C	2013	Avalanche	Body	Assist Step Controller																																																											
C	2013	Avalanche	Body	Body Control Module																																																											
C	2013	Avalanche	Body	Body Control Module (aux.)																																																											
C	2013	Avalanche	Body	Digital Radio Receiver																																																											
C	2013	Avalanche	Body	Driver Door Switch																																																											
C	2013	Avalanche	Body	HVAC Control Module Auto																																																											
C	2013	Avalanche	Body	HVAC Control Module Manual																																																											
C	2013	Avalanche	Body	Instrument Panel Cluster																																																											
C	2013	Avalanche	Body	Memory Seat Module																																																											
C	2013	Avalanche	Body	Navigation Radio																																																											
C	2013	Avalanche	Body	Park Assist Module																																																											
C	2013	Avalanche	Body	Passenger Door Switch																																																											
C	2013	Avalanche	Body	Passenger Presence System																																																											
C	2013	Avalanche	Body	Radio																																																											
C	2013	Avalanche	Body	Rear Heated Seat Module																																																											
C	2013	Avalanche	Body	Rear HVAC/RSA																																																											
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																											
C	2013	Avalanche	Body	Theft Deterrent Module																																																											
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																											
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																											
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																											
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																											
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																											
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																											
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																											
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
C	2013	Captiva	Chassis	Electronic Brake Control Module																																																											
C	2013	Captiva	Chassis	Parking Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																											
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																											
C	2013	Captiva	Body	Auxiliary Body Control Module																																																											
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2013	Captiva	Body	Instrument Cluster																																																											
C	2013	Captiva	Body	Headlamp Control Module																																																											
C	2013	Captiva	Body	HVAC Control Module																																																											
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
C	2013	Captiva	Body	Theft Deterrent Module																																																											
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																											
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Cheyenne	Body	Amplifier (Bose)																																																											
C	2013	Cheyenne	Body	Body Control Module																																																											
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																											
C	2013	Cheyenne	Body	Digital Radio Receiver																																																											
C	2013	Cheyenne	Body	Driver Door Switch																																																											
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																											
C	2013	Cheyenne	Body	Park Assist Module																																																											
C	2013	Cheyenne	Body	Passenger Door Switch																																																											
C	2013	Cheyenne	Body	Passenger Presence System																																																											
C	2013	Cheyenne	Body	Rear Heated Seat Module																																																											
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																											
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
C	2013	Cheyenne	Body	Theft Deterrent Module																																																											
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																													V	V	V	V																											
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																											
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																											
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2013	Suburban	Chassis	Electronic Suspension Control																																																											
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Suburban	Body	Amplifier (Bose)																																																												
C	2013	Suburban	Body	Assist Step Controller																																																												
C	2013	Suburban	Body	Body Control Module																																																												
C	2013	Suburban	Body	Body Control Module (aux.)																																																												
C	2013	Suburban	Body	Digital Radio Receiver																																																												
C	2013	Suburban	Body	Driver Door Switch																																																												
C	2013	Suburban	Body	HVAC Control Module Auto																																																												
C	2013	Suburban	Body	HVAC Control Module Manual																																																												
C	2013	Suburban	Body	Instrument Panel Cluster																																																												
C	2013	Suburban	Body	Left Side Object Detection Module																																																												
C	2013	Suburban	Body	Lift Gate Module																																																												
C	2013	Suburban	Body	Memory Seat Module																																																												
C	2013	Suburban	Body	Navigation Radio																																																												
C	2013	Suburban	Body	Park Assist Module																																																												
C	2013	Suburban	Body	Passenger Door Switch																																																												
C	2013	Suburban	Body	Passenger Presence System																																																												
C	2013	Suburban	Body	Radio																																																												
C	2013	Suburban	Body	Rear Heated Seat Module																																																												
C	2013	Suburban	Body	Rear HVAC/RSA																																																												
C	2013	Suburban	Body	Right Side Object Detection Module																																																												
C	2013	Suburban	Body	Supplemental Inflatable Restraint																																																												
C	2013	Suburban	Body	Theft Deterrent Module																																																												
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																							V																																					
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																							V																																					
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																												
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V	V	V																																																							
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2013	Silverado	Chassis	Electronic Suspension Control																																																												
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2013	Silverado	Body	Amplifier (Bose)																																																												
C	2013	Silverado	Body	Body Control Module																																																												
C	2013	Silverado	Body	Body Control Module (aux.)																																																												
C	2013	Silverado	Body	Digital Radio Receiver																																																												
C	2013	Silverado	Body	Driver Door Switch																																																												
C	2013	Silverado	Body	HVAC Control Module Auto																																																												
C	2013	Silverado	Body	HVAC Control Module Manual																																																												
C	2013	Silverado	Body	Instrument Panel Cluster																																																												
C	2013	Silverado	Body	Memory Seat Module																																																												
C	2013	Silverado	Body	Navigation Radio																																																												
C	2013	Silverado	Body	Park Assist Module																																																												
C	2013	Silverado	Body	Passenger Door Switch																																																												
C	2013	Silverado	Body	Passenger Presence System																																																												
C	2013	Silverado	Body	Radio																																																												
C	2013	Silverado	Body	Rear Heated Seat Module																																																												
C	2013	Silverado	Body	Rear HVAC/RSA																																																												
C	2013	Silverado	Body	Supplemental Inflatable Restraint																																																												
C	2013	Silverado	Body	Theft Deterrent Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																												
C	2013	Silverado Hybrid	Body	Body Control Module																																																												
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																												
C	2013	Silverado Hybrid	Body	Driver Door Switch																																																												
C	2013	Silverado Hybrid	Body	Heated Seat Module																																																												
C	2013	Silverado Hybrid	Body	HVAC Control Module																																																												
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
C	2013	Silverado Hybrid	Body	Navigation Radio																																																												
C	2013	Silverado Hybrid	Body	Park Assist Module																																																												
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																																												
C	2013	Silverado Hybrid	Body	Passenger Presence System																																																												
C	2013	Silverado Hybrid	Body	Radio																																																												
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																												V	V	V	V																											
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2013	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe	Body	Amplifier (Bose)																																																											
C	2013	Tahoe	Body	Assist Step Controller																																																											
C	2013	Tahoe	Body	Body Control Module																																																											
C	2013	Tahoe	Body	Body Control Module (aux.)																																																											
C	2013	Tahoe	Body	Digital Radio Receiver																																																											
C	2013	Tahoe	Body	Driver Door Switch																																																											
C	2013	Tahoe	Body	HVAC Control Module Auto																																																											
C	2013	Tahoe	Body	HVAC Control Module Manual																																																											
C	2013	Tahoe	Body	Instrument Panel Cluster																																																											
C	2013	Tahoe	Body	Left Side Object Detection Module																																																											
C	2013	Tahoe	Body	Lift Gate Module																																																											
C	2013	Tahoe	Body	Memory Seat Module																																																											
C	2013	Tahoe	Body	Navigation Radio																																																											
C	2013	Tahoe	Body	Park Assist Module																																																											
C	2013	Tahoe	Body	Passenger Door Switch																																																											
C	2013	Tahoe	Body	Passenger Presence System																																																											
C	2013	Tahoe	Body	Radio																																																											
C	2013	Tahoe	Body	Rear Heated Seat Module																																																											
C	2013	Tahoe	Body	Rear HVAC/RSA																																																											
C	2013	Tahoe	Body	Right Side Object Detection Module																																																											
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																											
C	2013	Tahoe	Body	Theft Deterrent Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2013	Tahoe Hybrid	Body	Body Control Module																																																											
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																																											
C	2013	Tahoe Hybrid	Body	HVAC Control Module																																																											
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2013	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2013	Tahoe Hybrid	Body	Navigation Radio																																																										
C	2013	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2013	Tahoe Hybrid	Body	Radio																																																										
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
C	2014	Captiva (3GN)	Body	Body Control Module																																																										
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Captiva (3GN)	Body	Passenger Presence Module																																																										
C	2014	Captiva (3GN)	Body	Instrument Cluster																																																										
C	2014	Captiva (3GN)	Body	Radio																																																										
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Captiva (3GN)	Body	HVAC Control Module																																																										
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																										
C	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																												
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																												
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																												
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																												
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																												
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																												
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																												
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Captiva (Other)	Body	Instrument Cluster																																																												
C	2014	Captiva (Other)	Body	Headlamp Control Module																																																												
C	2014	Captiva (Other)	Body	HVAC Control Module																																																												
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																												
C	2014	Captiva (Other)	Body	Theft Deterrent Module																																																												
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																												
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																												
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																												
C	2014	Cheyenne	Chassis	Power Steering Control Module																																																												
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2014	Cheyenne	Body	Body Control Module																																																												
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Cheyenne	Body	Passenger Presence Module																																																												
C	2014	Cheyenne	Body	Instrument Cluster																																																												
C	2014	Cheyenne	Body	Radio Control																																																												
C	2014	Cheyenne	Body	HVAC Control																																																												
C	2014	Cheyenne	Body	Radio																																																											
C	2014	Cheyenne	Body	Amplifier																																																											
C	2014	Cheyenne	Body	Media Disc Player																																																											
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																											
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																											
C	2014	Cheyenne	Body	HVAC Control Module																																																											
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																											
C	2014	Cheyenne	Body	Parking Assist Control Module																																																											
C	2014	Cheyenne	Body	Frontview Camera Module																																																											
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado	Chassis	Parking Brake Control Module																																																										
C	2014	Silverado	Chassis	Power Steering Control Module																																																										
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Silverado	Body	Body Control Module																																																										
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado	Body	Passenger Presence Module																																																										
C	2014	Silverado	Body	Instrument Cluster																																																										
C	2014	Silverado	Body	Radio Control																																																										
C	2014	Silverado	Body	HVAC Control																																																										
C	2014	Silverado	Body	Radio																																																										
C	2014	Silverado	Body	Amplifier																																																										
C	2014	Silverado	Body	Media Disc Player																																																										
C	2014	Silverado	Body	Human Machine Interface Control Module																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2014	Silverado	Body	Parking Assist Control Module																																																										
C	2014	Silverado	Body	Frontview Camera Module																																																										
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																															
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																										
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Suspension Control Module																																																										
C	2014	Silverado HD	Body	Body Control Module																																																										
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado HD	Body	Passenger Presence Module																																																										
C	2014	Silverado HD	Body	Instrument Cluster																																																										
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
C	2014	Silverado HD	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2014	Silverado HD	Body	Navigation Radio																																																										
C	2014	Silverado HD	Body	Uplevel Radio																																																											
C	2014	Silverado HD	Body	Amplifier																																																										
C	2014	Silverado HD	Body	Rear Audio Control Module																																																										
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																										
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																										
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																										V																
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																										V																
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																										V																
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																										V																
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Silverado HD	Body	Seat Memory Control Module																																																										
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																										
C	2014	Silverado HD	Body	Parking Assist Control Module																																																										
C	2014	Silverado HD	Body	Theft Deterrent Module																																																										
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																										
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2014	Suburban	Chassis	Parking Brake Control Module																																																										
C	2014	Suburban	Chassis	Suspension Control Module																																																										
C	2014	Suburban	Body	Body Control Module																																																										
C	2014	Suburban	Body	Auxiliary Body Control Module																																																										
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Suburban	Body	Passenger Presence Module																																																										
C	2014	Suburban	Body	Instrument Cluster																																																										
C	2014	Suburban	Body	Base Radio																																																										
C	2014	Suburban	Body	Navigation Radio																																																										
C	2014	Suburban	Body	Uplevel Radio																																																										
C	2014	Suburban	Body	Amplifier																																																										
C	2014	Suburban	Body	Rear Audio Control Module																																																										
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																										
C	2014	Suburban	Body	Personal Audio Link Control Module																																																										
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																										V																
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																										V																
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Suburban	Body	Liftgate Control Module																																																										
C	2014	Suburban	Body	Seat Memory Control Module																																																										
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2014	Suburban	Body	Assist Step Control Module																																																								
C	2014	Suburban	Body	Right Side Object Detection Control Module																																																								
C	2014	Suburban	Body	Left Side Object Detection Control Module																																																								
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																								
C	2014	Suburban	Body	Parking Assist Control Module																																																								
C	2014	Suburban	Body	Theft Deterrent Module																																																								
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																								
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																								
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																								
C	2014	Tahoe	Chassis	Suspension Control Module																																																								
C	2014	Tahoe	Body	Body Control Module																																																								
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																								
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Tahoe	Body	Passenger Presence Module																																																								
C	2014	Tahoe	Body	Instrument Cluster																																																								
C	2014	Tahoe	Body	Base Radio																																																								
C	2014	Tahoe	Body	Navigation Radio																																																								
C	2014	Tahoe	Body	Uplevel Radio																																																								
C	2014	Tahoe	Body	Amplifier																																																								
C	2014	Tahoe	Body	Rear Audio Control Module																																																								
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																								
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																								
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																								
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																											V													
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																											V													
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																								
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																								
C	2014	Tahoe	Body	Liftgate Control Module																																																								
C	2014	Tahoe	Body	Seat Memory Control Module																																																								
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																																								
C	2014	Tahoe	Body	Assist Step Control Module																																																								
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																																								
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																																								
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																								
C	2014	Tahoe	Body	Parking Assist Control Module																																																								
C	2014	Tahoe	Body	Theft Deterrent Module																																																								
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																								
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																								
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																								
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2015	Captiva (3GN)	Body	Body Control Module																																																											
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																																											
C	2015	Captiva (3GN)	Body	Instrument Cluster																																																											
C	2015	Captiva (3GN)	Body	Radio																																																											
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																											
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																											
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																											
C	2015	Captiva (3GN)	Body	HVAC Control Module																																																											
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																											
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																											
C	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																											
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																											
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																											
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																											
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																											
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Captiva (Other)	Body	Instrument Cluster																																																											
C	2015	Captiva (Other)	Body	Headlamp Control Module																																																											
C	2015	Captiva (Other)	Body	HVAC Control Module																																																											
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
C	2015	Captiva (Other)	Body	Theft Deterrent Module																																																											
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																											
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																									
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																									
C	2015	Cheyenne	Chassis	Power Steering Control Module																																																									
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2015	Cheyenne	Chassis	Suspension Control Module																																																									
C	2015	Cheyenne	Body	Body Control Module																																																									
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	Cheyenne	Body	Passenger Presence Module																																																									
C	2015	Cheyenne	Body	Instrument Cluster																																																									
C	2015	Cheyenne	Body	Radio Controls																																																									
C	2015	Cheyenne	Body	HVAC Controls																																																									
C	2015	Cheyenne	Body	Radio																																																									
C	2015	Cheyenne	Body	Amplifier																																																									
C	2015	Cheyenne	Body	Media Disc Player																																																									
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																									
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																									
C	2015	Cheyenne	Body	HVAC Control Module																																																									
C	2015	Cheyenne	Body	Parking Assist Control Module																																																									
C	2015	Cheyenne	Body	Frontview Camera Module																																																									
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																															
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																									
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																									
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																									
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																									
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2015	Silverado	Chassis	Electronic Brake Control Module																																																									
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																									
C	2015	Silverado	Chassis	Power Steering Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Silverado	Chassis	Suspension Control Module																																																												
C	2015	Silverado	Body	Body Control Module																																																											
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Silverado	Body	Passenger Presence Module																																																											
C	2015	Silverado	Body	Instrument Cluster																																																											
C	2015	Silverado	Body	Radio Controls																																																										
C	2015	Silverado	Body	HVAC Controls																																																										
C	2015	Silverado	Body	Radio																																																										
C	2015	Silverado	Body	Amplifier																																																										
C	2015	Silverado	Body	Media Disc Player																																																										
C	2015	Silverado	Body	Human Machine Interface Control Module																																																										
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																										
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2015	Silverado	Body	Parking Assist Control Module																																																										
C	2015	Silverado	Body	Frontview Camera Module																																																										
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Suburban	Chassis	Parking Brake Control Module																																																										
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Suburban	Chassis	Power Steering Control Module																																																										
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Suburban	Chassis	Suspension Control Module																																																										
C	2015	Suburban	Body	Body Control Module																																																										
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Suburban	Body	Passenger Presence Module																																																										
C	2015	Suburban	Body	Instrument Cluster																																																										
C	2015	Suburban	Body	Radio Controls																																																										
C	2015	Suburban	Body	HVAC Controls																																																										
C	2015	Suburban	Body	Radio																																																										
C	2015	Suburban	Body	Amplifier																																																										
C	2015	Suburban	Body	Media Disc Player																																																										
C	2015	Suburban	Body	Human Machine Interface Control Module																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Suburban	Body	HVAC Control Module																																																										
C	2015	Suburban	Body	Liftgate Control Module																																																										
C	2015	Suburban	Body	Keyless Entry Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2015	Suburban	Body	Assist Step Control Module																																																									
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																									
C	2015	Suburban	Body	Parking Assist Control Module																																																									
C	2015	Suburban	Body	Frontview Camera Module																																																									
C	2015	Suburban	Body	Steering Column Lock Control Module																																																									
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																									
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																									
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																									
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																									
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																									
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																																									
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																									
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																									
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																									
C	2015	Tahoe	Chassis	Power Steering Control Module																																																									
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2015	Tahoe	Chassis	Suspension Control Module																																																									
C	2015	Tahoe	Body	Body Control Module																																																									
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	Tahoe	Body	Passenger Presence Module																																																									
C	2015	Tahoe	Body	Instrument Cluster																																																									
C	2015	Tahoe	Body	Radio Controls																																																									
C	2015	Tahoe	Body	HVAC Controls																																																									
C	2015	Tahoe	Body	Radio																																																									
C	2015	Tahoe	Body	Amplifier																																																									
C	2015	Tahoe	Body	Media Disc Player																																																									
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																									
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																									
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																									
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2015	Tahoe	Body	HVAC Control Module																																																									
C	2015	Tahoe	Body	Liftgate Control Module																																																									
C	2015	Tahoe	Body	Keyless Entry Control Module																																																									
C	2015	Tahoe	Body	Assist Step Control Module																																																									
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																									
C	2015	Tahoe	Body	Parking Assist Control Module																																																									
C	2015	Tahoe	Body	Frontview Camera Module																																																									
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																									
C	2015	Tahoe	Body	Battery Energy Control Module																																																									
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																									
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																									
C	2016	Captiva (3GN)	Body	Body Control Module																																																									
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																									
C	2016	Captiva (3GN)	Body	Radio																																																									
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																									
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																									
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																									
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																									
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																									
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																									
C	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																									
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission	V					V	V	V	V	V																																															
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission	V					V	V	V	V	V																																															
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																									
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																									
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																									
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																									
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																									
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																									
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																									
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																									
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																									
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																									
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																									
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																									
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Captiva (Other)	Body	Instrument Cluster																																																									
C	2016	Captiva (Other)	Body	Headlamp Control Module																																																									
C	2016	Captiva (Other)	Body	Radio																																																									
C	2016	Captiva (Other)	Body	HVAC Control Module																																																									
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																									
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																									
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																									
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																									
C	2016	Captiva (Other)	Body	Theft Deterrent Module																																																									
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																											
C	2016	Cheyenne	Chassis	Power Steering Control Module																																																											
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Cheyenne	Chassis	Suspension Control Module																																																											
C	2016	Cheyenne	Body	Body Control Module																																																											
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Cheyenne	Body	Passenger Presence Module																																																											
C	2016	Cheyenne	Body	Instrument Cluster																																																											
C	2016	Cheyenne	Body	Radio Controls																																																											
C	2016	Cheyenne	Body	HVAC Controls																																																											
C	2016	Cheyenne	Body	Radio																																																											
C	2016	Cheyenne	Body	Amplifier																																																											
C	2016	Cheyenne	Body	Media Disc Player																																																											
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																											
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																											
C	2016	Cheyenne	Body	HVAC Control Module																																																											
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																											
C	2016	Cheyenne	Body	Parking Assist Control Module																																																											
C	2016	Cheyenne	Body	Frontview Camera Module																																																											
C	2016	Cheyenne	Body	Frontview Camera Module																																																											
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																											
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																											
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																											
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																											
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2016	Silverado	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2016	Silverado	Chassis	Power Steering Control Module																																																											
C	2016	Silverado	Chassis	Power Steering Control Module																																																												
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2016	Silverado	Chassis	Suspension Control Module																																																												
C	2016	Silverado	Body	Body Control Module																																																												
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Silverado	Body	Passenger Presence Module																																																												
C	2016	Silverado	Body	Instrument Cluster																																																												
C	2016	Silverado	Body	Radio Controls																																																												
C	2016	Silverado	Body	HVAC Controls																																																												
C	2016	Silverado	Body	Radio (IO3)																																																												
C	2016	Silverado	Body	Radio (IOB)																																																												
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																												
C	2016	Silverado	Body	Amplifier																																																												
C	2016	Silverado	Body	Media Disc Player																																																												
C	2016	Silverado	Body	Human Machine Interface Control Module																																																												
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																												
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																												
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																												
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																												
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																												
C	2016	Silverado	Body	Parking Assist Control Module																																																												
C	2016	Silverado	Body	Frontview Camera Module																																																												
C	2016	Silverado	Body	Frontview Camera Module																																																												
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2016	Suburban	Chassis	Electronic Brake Control Module																																																												
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																												
C	2016	Suburban	Chassis	Parking Brake Control Module																																																												
C	2016	Suburban	Chassis	Power Steering Control Module																																																												
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2016	Suburban	Chassis	Suspension Control Module																																																												
C	2016	Suburban	Body	Body Control Module																																																												
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Suburban	Body	Passenger Presence Module																																																												
C	2016	Suburban	Body	Instrument Cluster																																																												
C	2016	Suburban	Body	Radio Controls																																																												
C	2016	Suburban	Body	HVAC Controls																																																												
C	2016	Suburban	Body	Radio																																																												
C	2016	Suburban	Body	Amplifier																																																												
C	2016	Suburban	Body	Media Disc Player																																																												
C	2016	Suburban	Body	Human Machine Interface Control Module																																																												
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																																												
C	2016	Suburban	Body	HVAC Control Module																																																												
C	2016	Suburban	Body	Liftgate Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																										
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																										
C	2016	Suburban	Body	Keyless Entry Control Module																																																										
C	2016	Suburban	Body	Assist Step Control Module																																																										
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																										
C	2016	Suburban	Body	Parking Assist Control Module																																																										
C	2016	Suburban	Body	Frontview Camera Module																																																										
C	2016	Suburban	Body	Steering Column Lock Control Module																																																										
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																										
C	2016	Tahoe	Chassis	Power Steering Control Module																																																										
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Tahoe	Chassis	Suspension Control Module																																																										
C	2016	Tahoe	Body	Body Control Module																																																										
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Tahoe	Body	Passenger Presence Module																																																										
C	2016	Tahoe	Body	Instrument Cluster																																																										
C	2016	Tahoe	Body	Radio Controls																																																									
C	2016	Tahoe	Body	HVAC Controls																																																									
C	2016	Tahoe	Body	Radio																																																									
C	2016	Tahoe	Body	Amplifier																																																									
C	2016	Tahoe	Body	Media Disc Player																																																									
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																										
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																										
C	2016	Tahoe	Body	HVAC Control Module																																																										
C	2016	Tahoe	Body	Liftgate Control Module																																																										
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																										
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																										
C	2016	Tahoe	Body	Keyless Entry Control Module																																																										
C	2016	Tahoe	Body	Assist Step Control Module																																																										
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																										
C	2016	Tahoe	Body	Parking Assist Control Module																																																										
C	2016	Tahoe	Body	Frontview Camera Module																																																										
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																										
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																										
E	2004	ALL	Chassis	Electronic Brake Control Module																																																										
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2006	ALL	Chassis	Electronic Brake Control Module																																																										
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
E	2007	ALL	Chassis	Electronic Brake Control Module																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																										
G	2004	Express/Savana	Body	Body Control Module																																																										
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2004	Express/Savana	Body	OnStar																																																										
G	2004	Express/Savana	Body	Base Radio																																																										
G	2004	Express/Savana	Body	Uplevel Radio																																																										
G	2004	Express/Savana	Body	Remote Function Actuation																																																										
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																																										
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2005	Express/Savana	Chassis	VSES																																																									
G	2005	Express/Savana	Body	Body Control Module																																																									
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2005	Express/Savana	Body	Base Radio																																																									
G	2005	Express/Savana	Body	Uplevel Radio																																																									
G	2005	Express/Savana	Body	Remote Function Actuation																																																									
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2005	Express Access/Savana Pro	Chassis	VSES																																																									
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2005	Express Access/Savana Pro	Body	Base Radio																																																									
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2006	Express/Savana	Chassis	VSES																																																									
G	2006	Express/Savana	Body	Body Control Module																																																									
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2006	Express/Savana	Body	Passenger Presence System																																																									
G	2006	Express/Savana	Body	Base Radio																																																									
G	2006	Express/Savana	Body	Uplevel Radio																																																									
G	2006	Express/Savana	Body	Remote Function Actuation																																																									
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2006	Express Access/Savana Pro	Chassis	VSES																																																									
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2006	Express Access/Savana Pro	Body	Base Radio																																																									
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																												
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																												
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2007	Express/Savana	Body	Body Control Module																																																												
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																												
G	2007	Express/Savana	Body	Passenger Presence System																																																												
G	2007	Express/Savana	Body	Base Radio																																																												
G	2007	Express/Savana	Body	Uplevel Radio																																																												
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2007	Express Access/Savana Pro	Body	Radio																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express/Savana	Body	Body Control Module																																																										
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2008	Express/Savana	Body	Passenger Presence System																																																										
G	2008	Express/Savana	Body	Radio																																																										
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express/Savana	Body	Rollover Sensor																																																										
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2008	Express/Savana	Body	Theft Deterrent Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2008	Express Access/Savana Pro	Body	Radio																																																									
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2009	Express/Savana	Body	Body Control Module																																																									
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2009	Express/Savana	Body	Passenger Presence System																																																									
G	2009	Express/Savana	Body	Radio																																																									
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2009	Express/Savana	Body	Rollover Sensor																																																									
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2009	Express/Savana	Body	Theft Deterrent Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2009	Express Access/Savana Pro	Body	Radio																																																												
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																						
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express/Savana	Body	Body Control Module																																																												
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2010	Express/Savana	Body	Passenger Presence System																																																												
G	2010	Express/Savana	Body	Radio																																																											
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2010	Express/Savana	Body	Rollover Sensor																																																											
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2010	Express/Savana	Body	Theft Deterrent Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																						
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2010	Express Access/Savana Pro	Body	Radio																																																									
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																				
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2011	Express/Savana	Body	Body Control Module																																																									
G	2011	Express/Savana	Body	Digital Radio Receiver																																																									
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2011	Express/Savana	Body	Passenger Presence System																																																									
G	2011	Express/Savana	Body	Radio																																																								
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2011	Express/Savana	Body	Rollover Sensor																																																									
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2011	Express/Savana	Body	Theft Deterrent Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																				
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																							
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2011	Express Access/Savana Pro	Body	Body Control Module																																																							
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																							
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																							
G	2011	Express Access/Savana Pro	Body	Radio																																																							
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																							
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																							
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																							
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																							
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																							
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																							
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																							
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																							
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																		
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																							
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																							
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2012	Express/Savana	Body	Body Control Module																																																							
G	2012	Express/Savana	Body	Digital Radio Receiver																																																							
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2012	Express/Savana	Body	Passenger Presence System																																																							
G	2012	Express/Savana	Body	Radio																																																							
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
G	2012	Express/Savana	Body	Rollover Sensor																																																							
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																							
G	2012	Express/Savana	Body	Theft Deterrent Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																							
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																			
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2012	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2012	Express Access/Savana Pro	Body	Radio																																																								
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																			
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2013	Express/Savana	Body	Body Control Module																																																								
G	2013	Express/Savana	Body	Digital Radio Receiver																																																								
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2013	Express/Savana	Body	Navigation Radio																																																								
G	2013	Express/Savana	Body	Park Assist Module																																																								
G	2013	Express/Savana	Body	Passenger Presence System																																																								
G	2013	Express/Savana	Body	Radio																																																								
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2013	Express/Savana	Body	Rollover Sensor																																																								
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2013	Express/Savana	Body	Theft Deterrent Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																						
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2013	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																												
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																												
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2013	Express Access/Savana Pro	Body	Radio																																																												
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																												
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V																																																	
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
G	2014	Express	Chassis	Electronic Brake Control Module																																																												
G	2014	Express	Body	Body Control Module																																																												
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2014	Express	Body	Passenger Presence Module																																																												
G	2014	Express	Body	Rollover Sensor Module																																																												
G	2014	Express	Body	Instrument Cluster																																																												
G	2014	Express	Body	Chime Alarm Control Module																																																												
G	2014	Express	Body	Base Radio																																																												
G	2014	Express	Body	Navigation Radio																																																												
G	2014	Express	Body	Uplevel Radio																																																												
G	2014	Express	Body	Digital Radio Receiver Control Module																																																												
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																												
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																												
G	2014	Express	Body	Auxiliary Heater Control Module																																																												
G	2014	Express	Body	Remote Control Door Lock Receiver																																																												
G	2014	Express	Body	Parking Assist Control Module																																																												
G	2014	Express	Body	Theft Deterrent Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																											
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																											
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																											
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																											
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																											
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
G	2014	Savana	Chassis	Electronic Brake Control Module																																																											
G	2014	Savana	Body	Body Control Module																																																										
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2014	Savana	Body	Passenger Presence Module																																																										
G	2014	Savana	Body	Rollover Sensor Module																																																										
G	2014	Savana	Body	Instrument Cluster																																																									
G	2014	Savana	Body	Chime Alarm Control Module																																																									
G	2014	Savana	Body	Base Radio																																																									
G	2014	Savana	Body	Navigation Radio																																																								
G	2014	Savana	Body	Uplevel Radio																																																								
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																								
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																								
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																								
G	2014	Savana	Body	Auxiliary Heater Control Module																																																								
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																								
G	2014	Savana	Body	Parking Assist Control Module																																																							
G	2014	Savana	Body	Theft Deterrent Module																																																							
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																							
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																							
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																														
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																							
G	2015	Express	Chassis	Electronic Brake Control Module																																																							
G	2015	Express	Body	Body Control Module																																																						
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
G	2015	Express	Body	Rollover Sensor Module																																																					
G	2015	Express	Body	Instrument Cluster																																																					
G	2015	Express	Body	Digital Radio Receiver Control Module																																																					
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																					
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																					
G	2015	Express	Body	Auxiliary Heater Control Module																																																					
G	2015	Express	Body	Remote Control Door Lock Receiver																																																					
G	2015	Express	Body	Parking Assist Control Module																																																				

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2015	Express	Body	Theft Deterrent Module																																																											
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
G	2015	Savana	Chassis	Electronic Brake Control Module																																																											
G	2015	Savana	Body	Body Control Module																																																										
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2015	Savana	Body	Rollover Sensor Module																																																										
G	2015	Savana	Body	Instrument Cluster																																																										
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2015	Savana	Body	Auxiliary Heater Control Module																																																										
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
G	2015	Savana	Body	Parking Assist Control Module																																																										
G	2015	Savana	Body	Theft Deterrent Module																																																										
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
G	2016	Express	Chassis	Electronic Brake Control Module																																																											
G	2016	Express	Body	Body Control Module																																																										
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
G	2016	Express	Body	Instrument Cluster																																																										
G	2016	Express	Body	Chime Alarm Control Module																																																										
G	2016	Express	Body	Base Radio																																																										
G	2016	Express	Body	Navigation Radio																																																										
G	2016	Express	Body	Uplevel Radio																																																										
G	2016	Express	Body	Digital Radio Receiver Control Module																																																										
G	2016	Express	Body	Telematics Communication Interface Control Module																																																											
G	2016	Express	Body	Auxiliary Heater Control Module																																																											
G	2016	Express	Body	Remote Control Door Lock Receiver																																																										
G	2016	Express	Body	Parking Assist Control Module																																																										
G	2016	Express	Body	Theft Deterrent Module																																																										
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
G	2016	Savana	Chassis	Electronic Brake Control Module																																																											
G	2016	Savana	Body	Body Control Module																																																										
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2016	Savana	Body	Instrument Cluster																																																									
G	2016	Savana	Body	Chime Alarm Control Module																																																									
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																									
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																									
G	2016	Savana	Body	Auxiliary Heater Control Module																																																									
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																									
G	2016	Savana	Body	Parking Assist Control Module																																																									
G	2016	Savana	Body	Theft Deterrent Module																																																									
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2004	Express/Savana	Chassis	VSES																																																									
H	2004	Express/Savana	Body	Body Control Module																																																									
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2004	Express/Savana	Body	OnStar																																																									
H	2004	Express/Savana	Body	Base Radio																																																									
H	2004	Express/Savana	Body	Uplevel Radio																																																									
H	2004	Express/Savana	Body	Remote Function Actuation																																																									
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
H	2004	Express Access/Savana Pro	Chassis	VSES																																																									
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2004	Express Access/Savana Pro	Body	OnStar																																																									
H	2004	Express Access/Savana Pro	Body	Base Radio																																																									
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2005	Express/Savana	Chassis	VSES																																																									
H	2005	Express/Savana	Body	Body Control Module																																																									
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2005	Express/Savana	Body	Base Radio																																																									
H	2005	Express/Savana	Body	Uplevel Radio																																																									
H	2005	Express/Savana	Body	Remote Function Actuation																																																									
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2005	Express Access/Savana Pro	Chassis	VSES																																																										
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2005	Express Access/Savana Pro	Body	Base Radio																																																										
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2006	Express/Savana	Chassis	VSES																																																										
H	2006	Express/Savana	Body	Body Control Module																																																										
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2006	Express/Savana	Body	Passenger Presence System																																																										
H	2006	Express/Savana	Body	Base Radio																																																										
H	2006	Express/Savana	Body	Uplevel Radio																																																										
H	2006	Express/Savana	Body	Remote Function Actuation																																																										
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2006	Express Access/Savana Pro	Chassis	VSES																																																										
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2006	Express Access/Savana Pro	Body	Base Radio																																																										
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2007	Express/Savana	Body	Body Control Module																																																									
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2007	Express/Savana	Body	Passenger Presence System																																																									
H	2007	Express/Savana	Body	Base Radio																																																									
H	2007	Express/Savana	Body	Uplevel Radio																																																									
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2007	Express Access/Savana Pro	Body	Base Radio																																																									
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2008	Express/Savana	Body	Body Control Module																																																									
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2008	Express/Savana	Body	Passenger Presence System																																																									
H	2008	Express/Savana	Body	Radio																																																									
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2008	Express/Savana	Body	Rollover Sensor																																																									
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2008	Express/Savana	Body	Theft Deterrent Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module																																																										
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																																										
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express/Savana	Body	Theft Deterrent Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2010	Express/Savana	Body	Body Control Module																																																									
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2010	Express/Savana	Body	Passenger Presence System																																																									
H	2010	Express/Savana	Body	Radio																																																									
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2010	Express/Savana	Body	Rollover Sensor																																																									
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2010	Express/Savana	Body	Theft Deterrent Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2010	Express Access/Savana Pro	Body	Radio																																																									
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2011	Express/Savana	Body	Body Control Module																																																									
H	2011	Express/Savana	Body	Digital Radio Receiver																																																									
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2011	Express/Savana	Body	Passenger Presence System																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2011	Express/Savana	Body	Radio																																																									
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2011	Express/Savana	Body	Rollover Sensor																																																									
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2011	Express/Savana	Body	Theft Deterrent Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2011	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2011	Express Access/Savana Pro	Body	Radio																																																									
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2012	Express/Savana	Body	Body Control Module																																																									
H	2012	Express/Savana	Body	Digital Radio Receiver																																																									
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2012	Express/Savana	Body	Passenger Presence System																																																									
H	2012	Express/Savana	Body	Radio																																																									
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2012	Express/Savana	Body	Rollover Sensor																																																									
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2012	Express/Savana	Body	Theft Deterrent Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2012	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2012	Express Access/Savana Pro	Body	Radio																																																									
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2013	Express/Savana	Body	Body Control Module																																																									
H	2013	Express/Savana	Body	Digital Radio Receiver																																																									
H	2013	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2013	Express/Savana	Body	Navigation Radio																																																									
H	2013	Express/Savana	Body	Park Assist Module																																																									
H	2013	Express/Savana	Body	Passenger Presence System																																																									
H	2013	Express/Savana	Body	Radio																																																									
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2013	Express/Savana	Body	Rollover Sensor																																																									
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2013	Express/Savana	Body	Theft Deterrent Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2013	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2013	Express Access/Savana Pro	Body	Navigation Radio																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																																											
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																											
H	2013	Express Access/Savana Pro	Body	Radio																																																											
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																											
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																											
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																											
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																											
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																											
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																											
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																											
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																											
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
H	2014	Express	Chassis	Electronic Brake Control Module																																																											
H	2014	Express	Body	Body Control Module																																																										
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Express	Body	Passenger Presence Module																																																										
H	2014	Express	Body	Rollover Sensor Module																																																										
H	2014	Express	Body	Instrument Cluster																																																										
H	2014	Express	Body	Chime Alarm Control Module																																																										
H	2014	Express	Body	Base Radio																																																										
H	2014	Express	Body	Navigation Radio																																																										
H	2014	Express	Body	Uplevel Radio																																																										
H	2014	Express	Body	Digital Radio Receiver Control Module																																																										
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2014	Express	Body	Auxiliary Heater Control Module																																																										
H	2014	Express	Body	Remote Control Door Lock Receiver																																																										
H	2014	Express	Body	Parking Assist Control Module																																																										
H	2014	Express	Body	Theft Deterrent Module																																																										
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																											
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																											
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																											
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																											
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																											
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																											
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																											
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
H	2014	Savana	Chassis	Electronic Brake Control Module																																																												
H	2014	Savana	Body	Body Control Module																																																											
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2014	Savana	Body	Passenger Presence Module																																																											
H	2014	Savana	Body	Rollover Sensor Module																																																											
H	2014	Savana	Body	Instrument Cluster																																																											
H	2014	Savana	Body	Chime Alarm Control Module																																																											
H	2014	Savana	Body	Base Radio																																																											
H	2014	Savana	Body	Navigation Radio																																																											
H	2014	Savana	Body	Uplevel Radio																																																											
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																											
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											
H	2014	Savana	Body	Auxiliary Heater Control Module																																																											
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																											
H	2014	Savana	Body	Parking Assist Control Module																																																											
H	2014	Savana	Body	Theft Deterrent Module																																																											
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
H	2015	Express	Chassis	Electronic Brake Control Module																																																											
H	2015	Express	Body	Body Control Module																																																										
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
H	2015	Express	Body	Rollover Sensor Module																																																											
H	2015	Express	Body	Instrument Cluster																																																											
H	2015	Express	Body	Digital Radio Receiver Control Module																																																											
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																											
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																											
H	2015	Express	Body	Auxiliary Heater Control Module																																																											
H	2015	Express	Body	Remote Control Door Lock Receiver																																																											
H	2015	Express	Body	Parking Assist Control Module																																																											
H	2015	Express	Body	Theft Deterrent Module																																																											
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
H	2015	Savana	Chassis	Electronic Brake Control Module																																																											
H	2015	Savana	Body	Body Control Module																																																										
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2015	Savana	Body	Rollover Sensor Module																																																										
H	2015	Savana	Body	Instrument Cluster																																																										
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2015	Savana	Body	Auxiliary Heater Control Module																																																										
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2015	Savana	Body	Parking Assist Control Module																																																										
H	2015	Savana	Body	Theft Deterrent Module																																																										
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																															
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2016	Express	Chassis	Electronic Brake Control Module																																																										
H	2016	Express	Body	Body Control Module																																																										
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Express	Body	Instrument Cluster																																																										
H	2016	Express	Body	Chime Alarm Control Module																																																										
H	2016	Express	Body	Base Radio																																																										
H	2016	Express	Body	Navigation Radio																																																										
H	2016	Express	Body	Uplevel Radio																																																										
H	2016	Express	Body	Digital Radio Receiver Control Module																																																										
H	2016	Express	Body	Telematics Communication Interface Control Module																																																										
H	2016	Express	Body	Auxiliary Heater Control Module																																																										
H	2016	Express	Body	Remote Control Door Lock Receiver																																																										
H	2016	Express	Body	Parking Assist Control Module																																																										
H	2016	Express	Body	Theft Deterrent Module																																																										
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																															
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2016	Savana	Chassis	Electronic Brake Control Module																																																										
H	2016	Savana	Body	Body Control Module																																																										
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Savana	Body	Instrument Cluster																																																										
H	2016	Savana	Body	Chime Alarm Control Module																																																										
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
H	2016	Savana	Body	Auxiliary Heater Control Module																																																										
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2016	Savana	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2016	Savana	Body	Theft Deterrent Module																																																										
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																										
J	2004	ALL	Chassis	Electronic Brake Control Module																																																										
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																										
J	2007	ALL	Chassis	Electronic Brake Control Module																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																										
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																										
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																										
J	2013	Tracker	Chassis	Power Steering Control Module																																																										
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2013	Tracker	Body	Body Control Module																																																										
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2013	Tracker	Body	Passenger Presence Module																																																										
J	2013	Tracker	Body	Instrument Cluster																																																										
J	2013	Tracker	Body	Radio																																																										
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																																										
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2013	Tracker	Body	Front Seat Heating Control Module																																																										
J	2013	Tracker	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2013	Tracker	Body	Frontview Camera Module																																																											
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																											
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																											
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																											
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																											
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																											
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																											
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																											
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																											
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																											
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																											
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																											
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																											
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																											
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																											
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																											
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																											
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																											
J	2013	Trax	Chassis	Electronic Brake Control Module																																																											
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																											
J	2013	Trax	Chassis	Power Steering Control Module																																																											
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2013	Trax	Body	Body Control Module																																																										
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2013	Trax	Body	Passenger Presence Module																																																											
J	2013	Trax	Body	Instrument Cluster																																																											
J	2013	Trax	Body	Radio																																																											
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																											
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																											
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																											
J	2013	Trax	Body	Front Seat Heating Control Module																																																											
J	2013	Trax	Body	Parking Assist Control Module																																																											
J	2013	Trax	Body	Frontview Camera Module																																																											
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																												
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																												
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																												
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																												
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																												
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																												
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																												
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																												
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																												
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																												
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																												
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																												
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																												
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																																												
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																												
J	2014	Tracker	Chassis	Power Steering Control Module																																																												
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Tracker	Body	Body Control Module																																																												
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2014	Tracker	Body	Passenger Presence Module																																																												
J	2014	Tracker	Body	Instrument Cluster																																																												
J	2014	Tracker	Body	Radio																																																											
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																																												
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																																												
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																																												
J	2014	Tracker	Body	Front Seat Heating Control Module																																																												
J	2014	Tracker	Body	Parking Assist Control Module																																																												
J	2014	Tracker	Body	Frontview Camera Module																																																												
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2014	Trax	Chassis	Electronic Brake Control Module																																																										
J	2014	Trax	Chassis	Power Steering Control Module																																																										
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2014	Trax	Body	Body Control Module																																																									
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2014	Trax	Body	Passenger Presence Module																																																										
J	2014	Trax	Body	Instrument Cluster																																																									
J	2014	Trax	Body	Radio																																																									
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Trax	Body	Front Seat Heating Control Module																																																										
J	2014	Trax	Body	Parking Assist Control Module																																																										
J	2014	Trax	Body	Frontview Camera Module																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																											
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																											
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																											
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																											
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																											
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																											
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																											
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																																											
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																											
J	2015	Tracker	Chassis	Power Steering Control Module																																																											
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2015	Tracker	Body	Body Control Module																																																											
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2015	Tracker	Body	Instrument Cluster																																																											
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																																											
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																																											
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																																											
J	2015	Tracker	Body	Front Seat Heating Control Module																																																											
J	2015	Tracker	Body	Parking Assist Control Module																																																											
J	2015	Tracker	Body	Frontview Camera Module																																																											
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																											
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																											
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																											
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																											
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																											
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																											
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																											
J	2015	Trax	Powertrain	Chassis Control Module																																																											
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																											
J	2015	Trax	Chassis	Electronic Brake Control Module																																																											
J	2015	Trax	Chassis	Power Steering Control Module																																																											
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2015	Trax	Body	Body Control Module																																																											
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2015	Trax	Body	Passenger Presence Module																																																											
J	2015	Trax	Body	Instrument Cluster																																																											
J	2015	Trax	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Trax	Body	Seat Memory Control Module																																																										
J	2015	Trax	Body	Front Seat Heating Control Module																																																										
J	2015	Trax	Body	Right Side Object Detection Control Module																																																										
J	2015	Trax	Body	Left Side Object Detection Control Module																																																										
J	2015	Trax	Body	Parking Assist Control Module																																																										
J	2015	Trax	Body	Frontview Camera Module																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																										
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2016	Tracker	Chassis	Power Steering Control Module																																																										
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Tracker	Body	Body Control Module																																																										
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Tracker	Body	Instrument Cluster																																																										
J	2016	Tracker	Body	Trailer Interface Control Module																																																										
J	2016	Tracker	Body	Radio																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Tracker	Body	Front Seat Heating Control Module																																																										
J	2016	Tracker	Body	Parking Assist Control Module																																																										
J	2016	Tracker	Body	Frontview Camera Module																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2016	Trax	Powertrain	Chassis Control Module																																																										
J	2016	Trax	Chassis	Electronic Brake Control Module																																																										
J	2016	Trax	Chassis	Power Steering Control Module																																																										
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Trax	Body	Body Control Module																																																										
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Trax	Body	Passenger Presence Module																																																										
J	2016	Trax	Body	Instrument Cluster																																																										
J	2016	Trax	Body	Trailer Interface Control Module																																																										
J	2016	Trax	Body	Radio																																																										
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Trax	Body	Seat Memory Control Module																																																										
J	2016	Trax	Body	Front Seat Heating Control Module																																																										
J	2016	Trax	Body	Right Side Object Detection Control Module																																																										
J	2016	Trax	Body	Left Side Object Detection Control Module																																																										
J	2016	Trax	Body	Parking Assist Control Module																																																										
J	2016	Trax	Body	Frontview Camera Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
K	2004	ALL	Chassis	ESC																																																											
K	2004	ALL	Chassis	Rear Wheel Steering																																																											
K	2004	ALL	Chassis	Tire Pressure Monitor																																																											
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																											
K	2004	ALL	Chassis	VSES																																																										
K	2004	ALL	Body	Amplifier (Bose)																																																											
K	2004	ALL	Body	Body Control Module																																																											
K	2004	ALL	Body	CD Changer																																																											
K	2004	ALL	Body	Chime																																																											
K	2004	ALL	Body	Driver Door Module																																																											
K	2004	ALL	Body	Driver Seat Module																																																											
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2004	ALL	Body	Instrument Panel Cluster																																																											
K	2004	ALL	Body	OnStar																																																											
K	2004	ALL	Body	Passenger Door Module																																																											
K	2004	ALL	Body	Passenger Presence System																																																											
K	2004	ALL	Body	Radio Base																																																											
K	2004	ALL	Body	Radio Uplevel																																																											
K	2004	ALL	Body	Radio Navigation																																																											
K	2004	ALL	Body	Rear Aux. Climate Module																																																											
K	2004	ALL	Body	Rear HVAC																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2004	ALL	Body	Rear Seat Audio																																																					V			
K	2004	ALL	Body	Rear Seat Entertainment																																																							
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																							
K	2004	ALL	Body	Vehicle Theft Deterrent																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																							
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																							
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																							
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																							
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																							
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																							
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																							
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																							
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																							
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																							
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																							
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																							
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																							
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																							
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																							
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																							
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																							
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																							
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																							
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																							
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																							
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																							
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																							
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																							

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																									
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
K	2005	ALL	Chassis	ESC																																																									
K	2005	ALL	Chassis	Rear Wheel Steering																																																									
K	2005	ALL	Chassis	Tire Pressure Monitor																																																									
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																									
K	2005	ALL	Chassis	VSES																																																									
K	2005	ALL	Body	Amplifier (Bose)																																																									
K	2005	ALL	Body	Body Control Module																																																									
K	2005	ALL	Body	CD Changer																																																									
K	2005	ALL	Body	Chime																																																									
K	2005	ALL	Body	Disc Player and Video Display																																																									
K	2005	ALL	Body	Driver Door Module																																																									
K	2005	ALL	Body	Driver Seat Module																																																									
K	2005	ALL	Body	Generator Battery Control Module																																																									
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																									
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2005	ALL	Body	Instrument Panel Cluster																																																									
K	2005	ALL	Body	Passenger Door Module																																																									
K	2005	ALL	Body	Passenger Presence System																																																									
K	2005	ALL	Body	Base Radio																																																									
K	2005	ALL	Body	Uplevel Radio																																																									
K	2005	ALL	Body	Navigation Radio																																																									
K	2005	ALL	Body	Rear Aux. Climate Module																																																									
K	2005	ALL	Body	Rear HVAC																																																									
K	2005	ALL	Body	Rear Seat Audio																																																						V			
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2005	ALL	Body	Vehicle Theft Deterrent																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2006	ALL	Chassis	ESC																																																									
K	2006	ALL	Chassis	Tire Pressure Monitor																																																										
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2006	ALL	Chassis	VSES																																																									
K	2006	ALL	Body	Amplifier (Bose)																																																										
K	2006	ALL	Body	Body Control Module																																																									
K	2006	ALL	Body	CD Changer																																																									
K	2006	ALL	Body	Chime																																																									
K	2006	ALL	Body	Disc Player and Video Display																																																										
K	2006	ALL	Body	Driver Door Module																																																									
K	2006	ALL	Body	Driver Seat Module																																																									
K	2006	ALL	Body	Generator Battery Control Module																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2006	ALL	Body	Instrument Panel Cluster																																																										
K	2006	ALL	Body	Passenger Door Module																																																										
K	2006	ALL	Body	Passenger Presence System																																																										
K	2006	ALL	Body	Base Radio																																																										
K	2006	ALL	Body	Uplevel Radio																																																										
K	2006	ALL	Body	Navigation Radio																																																										
K	2006	ALL	Body	Rear Aux. Climate Module																																																										
K	2006	ALL	Body	Rear HVAC																																																										
K	2006	ALL	Body	Rear Seat Audio																																																							V			
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2006	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																																										
K	2007	Avalanche	Body	Amplifier (Bose)																																																										
K	2007	Avalanche	Body	Assist Step Controller																																																										
K	2007	Avalanche	Body	Body Control Module																																																										
K	2007	Avalanche	Body	Body Control Module (aux.)																																																										
K	2007	Avalanche	Body	Digital Radio Receiver																																																										
K	2007	Avalanche	Body	Driver Door Switch																																																										
K	2007	Avalanche	Body	HVAC Control Module Auto																																																										
K	2007	Avalanche	Body	HVAC Control Module Manual																																																										
K	2007	Avalanche	Body	Instrument Panel Cluster																																																										
K	2007	Avalanche	Body	Memory Seat Module																																																										
K	2007	Avalanche	Body	Park Assist Module																																																										
K	2007	Avalanche	Body	Passenger Door Switch																																																										
K	2007	Avalanche	Body	Passenger Presence System																																																										
K	2007	Avalanche	Body	Radio																																																										
K	2007	Avalanche	Body	Rear Heated Seat Module																																																										
K	2007	Avalanche	Body	Rear HVAC/RSA																																																										
K	2007	Avalanche	Body	Rollover Sensor																																																										
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2007	Avalanche	Body	Theft Deterrent Module																																																										
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Suburban	Chassis	Electronic Suspension Control																																																												
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																												
K	2007	Suburban	Body	Amplifier (Bose)																																																												
K	2007	Suburban	Body	Assist Step Controller																																																												
K	2007	Suburban	Body	Body Control Module																																																												
K	2007	Suburban	Body	Body Control Module (aux.)																																																												
K	2007	Suburban	Body	Digital Radio Receiver																																																												
K	2007	Suburban	Body	Driver Door Switch																																																												
K	2007	Suburban	Body	HVAC Control Module Auto																																																												
K	2007	Suburban	Body	HVAC Control Module Manual																																																												
K	2007	Suburban	Body	Instrument Panel Cluster																																																												
K	2007	Suburban	Body	Lift Gate Module																																																												
K	2007	Suburban	Body	Memory Seat Module																																																												
K	2007	Suburban	Body	Park Assist Module																																																												
K	2007	Suburban	Body	Passenger Door Switch																																																												
K	2007	Suburban	Body	Passenger Presence System																																																												
K	2007	Suburban	Body	Radio																																																											
K	2007	Suburban	Body	Rear Heated Seat Module																																																												
K	2007	Suburban	Body	Rear HVAC/RSA																																																												
K	2007	Suburban	Body	Rollover Sensor																																																												
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2007	Suburban	Body	Theft Deterrent Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Silverado	Chassis	Electronic Suspension Control																																																												
K	2007	Silverado	Chassis	Trailer Brake Control Module																																																												
K	2007	Silverado	Body	Amplifier (Bose)																																																												
K	2007	Silverado	Body	Body Control Module																																																												
K	2007	Silverado	Body	Body Control Module (aux.)																																																												
K	2007	Silverado	Body	Digital Radio Receiver																																																												
K	2007	Silverado	Body	Driver Door Switch																																																												
K	2007	Silverado	Body	HVAC Control Module Auto																																																												
K	2007	Silverado	Body	HVAC Control Module Manual																																																												
K	2007	Silverado	Body	Instrument Panel Cluster																																																												
K	2007	Silverado	Body	Memory Seat Module																																																												
K	2007	Silverado	Body	Park Assist Module																																																												
K	2007	Silverado	Body	Passenger Door Switch																																																												
K	2007	Silverado	Body	Passenger Presence System																																																												
K	2007	Silverado	Body	Radio																																																											
K	2007	Silverado	Body	Rear Heated Seat Module																																																												
K	2007	Silverado	Body	Rear HVAC/RSA																																																												
K	2007	Silverado	Body	Rollover Sensor																																																												
K	2007	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2007	Silverado	Body	Theft Deterrent Module																																																												
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2007	Tahoe	Body	Amplifier (Bose)																																																										
K	2007	Tahoe	Body	Assist Step Controller																																																										
K	2007	Tahoe	Body	Body Control Module																																																										
K	2007	Tahoe	Body	Body Control Module (aux.)																																																										
K	2007	Tahoe	Body	Digital Radio Receiver																																																										
K	2007	Tahoe	Body	Driver Door Switch																																																										
K	2007	Tahoe	Body	HVAC Control Module Auto																																																										
K	2007	Tahoe	Body	HVAC Control Module Manual																																																										
K	2007	Tahoe	Body	Instrument Panel Cluster																																																										
K	2007	Tahoe	Body	Lift Gate Module																																																										
K	2007	Tahoe	Body	Memory Seat Module																																																										
K	2007	Tahoe	Body	Park Assist Module																																																										
K	2007	Tahoe	Body	Passenger Door Switch																																																										
K	2007	Tahoe	Body	Passenger Presence System																																																										
K	2007	Tahoe	Body	Radio																																																										
K	2007	Tahoe	Body	Rear Heated Seat Module																																																										
K	2007	Tahoe	Body	Rear HVAC/RSA																																																										
K	2007	Tahoe	Body	Rollover Sensor																																																										
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2007	Tahoe	Body	Theft Deterrent Module																																																										
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																										
K	2008	Avalanche	Body	Amplifier (Bose)																																																										
K	2008	Avalanche	Body	Assist Step Controller																																																										
K	2008	Avalanche	Body	Body Control Module																																																										
K	2008	Avalanche	Body	Body Control Module (aux.)																																																										
K	2008	Avalanche	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2008	Avalanche	Body	Driver Door Switch																																																										
K	2008	Avalanche	Body	HVAC Control Module Auto																																																										
K	2008	Avalanche	Body	HVAC Control Module Manual																																																										
K	2008	Avalanche	Body	Instrument Panel Cluster																																																										
K	2008	Avalanche	Body	Memory Seat Module																																																										
K	2008	Avalanche	Body	Park Assist Module																																																										
K	2008	Avalanche	Body	Passenger Door Switch																																																										
K	2008	Avalanche	Body	Passenger Presence System																																																										
K	2008	Avalanche	Body	Radio																																																										
K	2008	Avalanche	Body	Rear Heated Seat Module																																																										
K	2008	Avalanche	Body	Rear HVAC/RSA																																																										
K	2008	Avalanche	Body	Rollover Sensor																																																										
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2008	Avalanche	Body	Theft Deterrent Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Suburban	Chassis	Electronic Suspension Control																																																										
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																										
K	2008	Suburban	Body	Amplifier (Bose)																																																										
K	2008	Suburban	Body	Assist Step Controller																																																										
K	2008	Suburban	Body	Body Control Module																																																										
K	2008	Suburban	Body	Body Control Module (aux.)																																																										
K	2008	Suburban	Body	Digital Radio Receiver																																																										
K	2008	Suburban	Body	Driver Door Switch																																																										
K	2008	Suburban	Body	HVAC Control Module Auto																																																										
K	2008	Suburban	Body	HVAC Control Module Manual																																																										
K	2008	Suburban	Body	Instrument Panel Cluster																																																										
K	2008	Suburban	Body	Lift Gate Module																																																										
K	2008	Suburban	Body	Memory Seat Module																																																										
K	2008	Suburban	Body	Park Assist Module																																																										
K	2008	Suburban	Body	Passenger Door Switch																																																										
K	2008	Suburban	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2008	Suburban	Body	Radio																																																									
K	2008	Suburban	Body	Rear Heated Seat Module																																																									
K	2008	Suburban	Body	Rear HVAC/RSA																																																									
K	2008	Suburban	Body	Rollover Sensor																																																									
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																																									
K	2008	Suburban	Body	Theft Deterrent Module																																																									
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																									
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																									
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																									
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2008	Silverado	Chassis	Electronic Suspension Control																																																									
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																									
K	2008	Silverado	Body	Amplifier (Bose)																																																									
K	2008	Silverado	Body	Body Control Module																																																									
K	2008	Silverado	Body	Body Control Module (aux.)																																																									
K	2008	Silverado	Body	Digital Radio Receiver																																																									
K	2008	Silverado	Body	Driver Door Switch																																																									
K	2008	Silverado	Body	HVAC Control Module Auto																																																									
K	2008	Silverado	Body	HVAC Control Module Manual																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2008	Silverado	Body	Instrument Panel Cluster																																																										
K	2008	Silverado	Body	Memory Seat Module																																																										
K	2008	Silverado	Body	Park Assist Module																																																										
K	2008	Silverado	Body	Passenger Door Switch																																																										
K	2008	Silverado	Body	Passenger Presence System																																																										
K	2008	Silverado	Body	Radio																																																										
K	2008	Silverado	Body	Rear Heated Seat Module																																																										
K	2008	Silverado	Body	Rear HVAC/RSA																																																										
K	2008	Silverado	Body	Rollover Sensor																																																										
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2008	Silverado	Body	Theft Deterrent Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2008	Tahoe	Body	Amplifier (Bose)																																																										
K	2008	Tahoe	Body	Assist Step Controller																																																										
K	2008	Tahoe	Body	Body Control Module																																																										
K	2008	Tahoe	Body	Body Control Module (aux.)																																																										
K	2008	Tahoe	Body	Digital Radio Receiver																																																										
K	2008	Tahoe	Body	Driver Door Switch																																																										
K	2008	Tahoe	Body	HVAC Control Module Auto																																																										
K	2008	Tahoe	Body	HVAC Control Module Manual																																																										
K	2008	Tahoe	Body	Instrument Panel Cluster																																																										
K	2008	Tahoe	Body	Lift Gate Module																																																										
K	2008	Tahoe	Body	Memory Seat Module																																																										
K	2008	Tahoe	Body	Park Assist Module																																																										
K	2008	Tahoe	Body	Passenger Door Switch																																																										
K	2008	Tahoe	Body	Passenger Presence System																																																										
K	2008	Tahoe	Body	Radio																																																										
K	2008	Tahoe	Body	Rear Heated Seat Module																																																										
K	2008	Tahoe	Body	Rear HVAC/RSA																																																										
K	2008	Tahoe	Body	Rollover Sensor																																																										
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2008	Tahoe	Body	Theft Deterrent Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2008	Tahoe Hybrid	Body	Body Control Module																																																										
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2008	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2008	Tahoe Hybrid	Body	Memory Seat Module																																																										
K	2008	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2008	Tahoe Hybrid	Body	Radio																																																										
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																										
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																										
K	2009	Avalanche	Body	Amplifier (Bose)																																																											
K	2009	Avalanche	Body	Assist Step Controller																																																											
K	2009	Avalanche	Body	Body Control Module																																																											
K	2009	Avalanche	Body	Body Control Module (aux.)																																																											
K	2009	Avalanche	Body	Digital Radio Receiver																																																											
K	2009	Avalanche	Body	Driver Door Switch																																																											
K	2009	Avalanche	Body	HVAC Control Module Auto																																																											
K	2009	Avalanche	Body	HVAC Control Module Manual																																																											
K	2009	Avalanche	Body	Instrument Panel Cluster																																																											
K	2009	Avalanche	Body	Memory Seat Module																																																											
K	2009	Avalanche	Body	Park Assist Module																																																											
K	2009	Avalanche	Body	Passenger Door Switch																																																											
K	2009	Avalanche	Body	Passenger Presence System																																																											
K	2009	Avalanche	Body	Radio																																																											
K	2009	Avalanche	Body	Rear Heated Seat Module																																																											
K	2009	Avalanche	Body	Rear HVAC/RSA																																																											
K	2009	Avalanche	Body	Rollover Sensor																																																											
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2009	Avalanche	Body	Theft Deterrent Module																																																											
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																											
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																											
K	2009	Cheyenne	Body	Amplifier (Bose)																																																											
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2009	Cheyenne	Body	Digital Radio Receiver																																																											
K	2009	Cheyenne	Body	Driver Door Switch																																																											
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2009	Cheyenne	Body	Park Assist Module																																																											
K	2009	Cheyenne	Body	Passenger Door Switch																																																											
K	2009	Cheyenne	Body	Passenger Presence System																																																											
K	2009	Cheyenne	Body	Rear Heated Seat Module																																																											
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2009	Cheyenne	Body	Rollover Sensor																																																											
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
K	2009	Cheyenne	Body	Theft Deterrent Module																																																											
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																												
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2009	Suburban	Chassis	Electronic Suspension Control																																																												
K	2009	Suburban	Chassis	Trailer Brake Control Module																																																												
K	2009	Suburban	Body	Amplifier (Bose)																																																												
K	2009	Suburban	Body	Assist Step Controller																																																												
K	2009	Suburban	Body	Body Control Module																																																												
K	2009	Suburban	Body	Body Control Module (aux.)																																																												
K	2009	Suburban	Body	Digital Radio Receiver																																																												
K	2009	Suburban	Body	Driver Door Switch																																																												
K	2009	Suburban	Body	HVAC Control Module Auto																																																												
K	2009	Suburban	Body	HVAC Control Module Manual																																																												
K	2009	Suburban	Body	Instrument Panel Cluster																																																												
K	2009	Suburban	Body	Left Side Object Detection Module																																																												
K	2009	Suburban	Body	Lift Gate Module																																																												
K	2009	Suburban	Body	Memory Seat Module																																																												
K	2009	Suburban	Body	Park Assist Module																																																												
K	2009	Suburban	Body	Passenger Door Switch																																																												
K	2009	Suburban	Body	Passenger Presence System																																																												
K	2009	Suburban	Body	Radio																																																											
K	2009	Suburban	Body	Rear Heated Seat Module																																																												
K	2009	Suburban	Body	Rear HVAC/RSA																																																												
K	2009	Suburban	Body	Right Side Object Detection Module																																																												
K	2009	Suburban	Body	Rollover Sensor																																																												
K	2009	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2009	Suburban	Body	Theft Deterrent Module																																																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2009	Silverado	Chassis	Electronic Suspension Control																																																										
K	2009	Silverado	Chassis	Trailer Brake Control Module																																																										
K	2009	Silverado	Body	Amplifier (Bose)																																																										
K	2009	Silverado	Body	Body Control Module																																																										
K	2009	Silverado	Body	Body Control Module (aux.)																																																										
K	2009	Silverado	Body	Digital Radio Receiver																																																										
K	2009	Silverado	Body	Driver Door Switch																																																										
K	2009	Silverado	Body	HVAC Control Module Auto																																																										
K	2009	Silverado	Body	HVAC Control Module Manual																																																										
K	2009	Silverado	Body	Instrument Panel Cluster																																																										
K	2009	Silverado	Body	Memory Seat Module																																																										
K	2009	Silverado	Body	Park Assist Module																																																										
K	2009	Silverado	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2009	Silverado	Body	Passenger Presence System																																																										
K	2009	Silverado	Body	Radio																																																										
K	2009	Silverado	Body	Rear Heated Seat Module																																																										
K	2009	Silverado	Body	Rear HVAC/RSA																																																										
K	2009	Silverado	Body	Rollover Sensor																																																										
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2009	Silverado	Body	Theft Deterrent Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Silverado Hybrid	Body	Body Control Module																																																										
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2009	Silverado Hybrid	Body	HVAC Control Module																																																										
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Silverado Hybrid	Body	Memory Seat Module																																																										
K	2009	Silverado Hybrid	Body	Park Assist Module																																																										
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2009	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2009	Silverado Hybrid	Body	Radio																																																										
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																										
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2009	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																																												
K	2009	Tahoe	Body	Amplifier (Bose)																																																												
K	2009	Tahoe	Body	Assist Step Controller																																																												
K	2009	Tahoe	Body	Body Control Module																																																												
K	2009	Tahoe	Body	Body Control Module (aux.)																																																												
K	2009	Tahoe	Body	Digital Radio Receiver																																																												
K	2009	Tahoe	Body	Driver Door Switch																																																												
K	2009	Tahoe	Body	HVAC Control Module Auto																																																												
K	2009	Tahoe	Body	HVAC Control Module Manual																																																												
K	2009	Tahoe	Body	Instrument Panel Cluster																																																												
K	2009	Tahoe	Body	Left Side Object Detection Module																																																												
K	2009	Tahoe	Body	Lift Gate Module																																																												
K	2009	Tahoe	Body	Memory Seat Module																																																												
K	2009	Tahoe	Body	Park Assist Module																																																												
K	2009	Tahoe	Body	Passenger Door Switch																																																												
K	2009	Tahoe	Body	Passenger Presence System																																																												
K	2009	Tahoe	Body	Radio																																																											
K	2009	Tahoe	Body	Rear Heated Seat Module																																																												
K	2009	Tahoe	Body	Rear HVAC/RSA																																																												
K	2009	Tahoe	Body	Right Side Object Detection Module																																																												
K	2009	Tahoe	Body	Rollover Sensor																																																												
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2009	Tahoe	Body	Theft Deterrent Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																												
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
K	2009	Tahoe Hybrid	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																																											
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																																											
K	2009	Tahoe Hybrid	Body	HVAC Control Module																																																											
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
K	2009	Tahoe Hybrid	Body	Park Assist Module																																																											
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																																											
K	2009	Tahoe Hybrid	Body	Radio																																																											
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																											
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																											
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																											
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2010	Avalanche	Chassis	Electronic Brake Control Module																																																											
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Avalanche	Body	Amplifier (Bose)																																																											
K	2010	Avalanche	Body	Assist Step Controller																																																											
K	2010	Avalanche	Body	Body Control Module																																																											
K	2010	Avalanche	Body	Body Control Module (aux.)																																																											
K	2010	Avalanche	Body	Digital Radio Receiver																																																											
K	2010	Avalanche	Body	Driver Door Switch																																																											
K	2010	Avalanche	Body	HVAC Control Module Auto																																																											
K	2010	Avalanche	Body	HVAC Control Module Manual																																																											
K	2010	Avalanche	Body	Instrument Panel Cluster																																																											
K	2010	Avalanche	Body	Memory Seat Module																																																											
K	2010	Avalanche	Body	Park Assist Module																																																											
K	2010	Avalanche	Body	Passenger Door Switch																																																											
K	2010	Avalanche	Body	Passenger Presence System																																																											
K	2010	Avalanche	Body	Radio																																																											
K	2010	Avalanche	Body	Rear Heated Seat Module																																																											
K	2010	Avalanche	Body	Rear HVAC/RSA																																																											
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2010	Avalanche	Body	Theft Deterrent Module																																																											
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																									
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																									
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Cheyenne	Body	Amplifier (Bose)																																																									
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																									
K	2010	Cheyenne	Body	Digital Radio Receiver																																																									
K	2010	Cheyenne	Body	Driver Door Switch																																																									
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																									
K	2010	Cheyenne	Body	Park Assist Module																																																									
K	2010	Cheyenne	Body	Passenger Door Switch																																																									
K	2010	Cheyenne	Body	Passenger Presence System																																																									
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																									
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																									
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																									
K	2010	Cheyenne	Body	Theft Deterrent Module																																																									
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																													V	V	V	V																									
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																									
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																									
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																													V	V	V	V																									
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																									
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																									
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																									
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																									
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																									
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
K	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																									
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2010	Suburban	Chassis	Electronic Suspension Control																																																									
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Suburban	Body	Amplifier (Bose)																																																									
K	2010	Suburban	Body	Assist Step Controller																																																									
K	2010	Suburban	Body	Body Control Module																																																									
K	2010	Suburban	Body	Body Control Module (aux.)																																																									
K	2010	Suburban	Body	Digital Radio Receiver																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2010	Suburban	Body	Driver Door Switch																																																											
K	2010	Suburban	Body	HVAC Control Module Auto																																																												
K	2010	Suburban	Body	HVAC Control Module Manual																																																												
K	2010	Suburban	Body	Instrument Panel Cluster																																																												
K	2010	Suburban	Body	Left Side Object Detection Module																																																												
K	2010	Suburban	Body	Lift Gate Module																																																												
K	2010	Suburban	Body	Memory Seat Module																																																												
K	2010	Suburban	Body	Park Assist Module																																																												
K	2010	Suburban	Body	Passenger Door Switch																																																												
K	2010	Suburban	Body	Passenger Presence System																																																												
K	2010	Suburban	Body	Radio																																																												
K	2010	Suburban	Body	Rear Heated Seat Module																																																												
K	2010	Suburban	Body	Rear HVAC/RSA																																																												
K	2010	Suburban	Body	Right Side Object Detection Module																																																												
K	2010	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2010	Suburban	Body	Theft Deterrent Module																																																												
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																												
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2010	Silverado	Chassis	Electronic Suspension Control																																																												
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2010	Silverado	Body	Amplifier (Bose)																																																												
K	2010	Silverado	Body	Body Control Module																																																												
K	2010	Silverado	Body	Body Control Module (aux.)																																																												
K	2010	Silverado	Body	Digital Radio Receiver																																																												
K	2010	Silverado	Body	Driver Door Switch																																																												
K	2010	Silverado	Body	HVAC Control Module Auto																																																												
K	2010	Silverado	Body	HVAC Control Module Manual																																																												
K	2010	Silverado	Body	Instrument Panel Cluster																																																												
K	2010	Silverado	Body	Memory Seat Module																																																												
K	2010	Silverado	Body	Park Assist Module																																																												
K	2010	Silverado	Body	Passenger Door Switch																																																												
K	2010	Silverado	Body	Passenger Presence System																																																												
K	2010	Silverado	Body	Radio																																																												
K	2010	Silverado	Body	Rear Heated Seat Module																																																												
K	2010	Silverado	Body	Rear HVAC/RSA																																																												
K	2010	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2010	Silverado	Body	Theft Deterrent Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Silverado Hybrid	Body	Body Control Module																																																												
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2010	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2010	Silverado Hybrid	Body	Heated Seat Module																																																												
K	2010	Silverado Hybrid	Body	HVAC Control Module																																																												
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2010	Silverado Hybrid	Body	Park Assist Module																																																												
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2010	Silverado Hybrid	Body	Passenger Presence System																																																												
K	2010	Silverado Hybrid	Body	Radio																																																												
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Tahoe	Body	Amplifier (Bose)																																																										
K	2010	Tahoe	Body	Assist Step Controller																																																										
K	2010	Tahoe	Body	Body Control Module																																																										
K	2010	Tahoe	Body	Body Control Module (aux.)																																																										
K	2010	Tahoe	Body	Digital Radio Receiver																																																										
K	2010	Tahoe	Body	Driver Door Switch																																																										
K	2010	Tahoe	Body	HVAC Control Module Auto																																																										
K	2010	Tahoe	Body	HVAC Control Module Manual																																																										
K	2010	Tahoe	Body	Instrument Panel Cluster																																																										
K	2010	Tahoe	Body	Left Side Object Detection Module																																																										
K	2010	Tahoe	Body	Lift Gate Module																																																										
K	2010	Tahoe	Body	Memory Seat Module																																																										
K	2010	Tahoe	Body	Park Assist Module																																																										
K	2010	Tahoe	Body	Passenger Door Switch																																																										
K	2010	Tahoe	Body	Passenger Presence System																																																										
K	2010	Tahoe	Body	Radio																																																										
K	2010	Tahoe	Body	Rear Heated Seat Module																																																										
K	2010	Tahoe	Body	Rear HVAC/RSA																																																										
K	2010	Tahoe	Body	Right Side Object Detection Module																																																										
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2010	Tahoe	Body	Theft Deterrent Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Tahoe Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2010	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2010	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2010	Tahoe Hybrid	Body	Radio																																																										
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2011	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Avalanche	Body	Amplifier (Bose)																																																										
K	2011	Avalanche	Body	Assist Step Controller																																																										
K	2011	Avalanche	Body	Body Control Module																																																										
K	2011	Avalanche	Body	Body Control Module (aux.)																																																										
K	2011	Avalanche	Body	Digital Radio Receiver																																																										
K	2011	Avalanche	Body	Driver Door Switch																																																										
K	2011	Avalanche	Body	HVAC Control Module Auto																																																										
K	2011	Avalanche	Body	HVAC Control Module Manual																																																										
K	2011	Avalanche	Body	Instrument Panel Cluster																																																										
K	2011	Avalanche	Body	Memory Seat Module																																																										
K	2011	Avalanche	Body	Park Assist Module																																																										
K	2011	Avalanche	Body	Passenger Door Switch																																																										
K	2011	Avalanche	Body	Passenger Presence System																																																										
K	2011	Avalanche	Body	Radio																																																										
K	2011	Avalanche	Body	Rear Heated Seat Module																																																										
K	2011	Avalanche	Body	Rear HVAC/RSA																																																										
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2011	Avalanche	Body	Theft Deterrent Module																																																										
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Cheyenne	Body	Amplifier (Bose)																																																										
K	2011	Cheyenne	Body	Body Control Module																																																										
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2011	Cheyenne	Body	Digital Radio Receiver																																																										
K	2011	Cheyenne	Body	Driver Door Switch																																																										
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2011	Cheyenne	Body	Park Assist Module																																																										
K	2011	Cheyenne	Body	Passenger Door Switch																																																										
K	2011	Cheyenne	Body	Passenger Presence System																																																										
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2011	Cheyenne	Body	Theft Deterrent Module																																																										
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																												V	V	V	V																										
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																												V	V	V	V																										
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2011	Suburban	Chassis	Electronic Suspension Control																																																										
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Suburban	Body	Amplifier (Bose)																																																										
K	2011	Suburban	Body	Assist Step Controller																																																										
K	2011	Suburban	Body	Body Control Module																																																										
K	2011	Suburban	Body	Body Control Module (aux.)																																																										
K	2011	Suburban	Body	Digital Radio Receiver																																																										
K	2011	Suburban	Body	Driver Door Switch																																																										
K	2011	Suburban	Body	HVAC Control Module Auto																																																										
K	2011	Suburban	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2011	Suburban	Body	Instrument Panel Cluster																																																										
K	2011	Suburban	Body	Left Side Object Detection Module																																																											
K	2011	Suburban	Body	Lift Gate Module																																																											
K	2011	Suburban	Body	Memory Seat Module																																																											
K	2011	Suburban	Body	Park Assist Module																																																											
K	2011	Suburban	Body	Passenger Door Switch																																																											
K	2011	Suburban	Body	Passenger Presence System																																																											
K	2011	Suburban	Body	Radio																																																											
K	2011	Suburban	Body	Rear Heated Seat Module																																																											
K	2011	Suburban	Body	Rear HVAC/RSA																																																											
K	2011	Suburban	Body	Right Side Object Detection Module																																																											
K	2011	Suburban	Body	Supplemental Inflatable Restraint																																																											
K	2011	Suburban	Body	Theft Deterrent Module																																																											
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module																																																											
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module																																																											
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																							V																																			
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																							V																																			
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V	V	V																																																						
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																											
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																						
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																											
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2011	Silverado	Chassis	Electronic Suspension Control																																																												
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2011	Silverado	Body	Amplifier (Bose)																																																												
K	2011	Silverado	Body	Body Control Module																																																												
K	2011	Silverado	Body	Body Control Module (aux.)																																																												
K	2011	Silverado	Body	Digital Radio Receiver																																																												
K	2011	Silverado	Body	Driver Door Switch																																																												
K	2011	Silverado	Body	HVAC Control Module Auto																																																												
K	2011	Silverado	Body	HVAC Control Module Manual																																																												
K	2011	Silverado	Body	Instrument Panel Cluster																																																												
K	2011	Silverado	Body	Memory Seat Module																																																												
K	2011	Silverado	Body	Park Assist Module																																																												
K	2011	Silverado	Body	Passenger Door Switch																																																												
K	2011	Silverado	Body	Passenger Presence System																																																												
K	2011	Silverado	Body	Radio																																																												
K	2011	Silverado	Body	Rear Heated Seat Module																																																												
K	2011	Silverado	Body	Rear HVAC/RSA																																																												
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2011	Silverado	Body	Theft Deterrent Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2011	Silverado Hybrid	Body	Body Control Module																																																												
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																												
K	2011	Silverado Hybrid	Body	HVAC Control Module																																																												
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2011	Silverado Hybrid	Body	Park Assist Module																																																												
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2011	Silverado Hybrid	Body	Passenger Presence System																																																												
K	2011	Silverado Hybrid	Body	Radio																																																												
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																											
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2011	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																											
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Tahoe	Body	Amplifier (Bose)																																																											
K	2011	Tahoe	Body	Assist Step Controller																																																											
K	2011	Tahoe	Body	Body Control Module																																																											
K	2011	Tahoe	Body	Body Control Module (aux.)																																																											
K	2011	Tahoe	Body	Digital Radio Receiver																																																											
K	2011	Tahoe	Body	Driver Door Switch																																																											
K	2011	Tahoe	Body	HVAC Control Module Auto																																																											
K	2011	Tahoe	Body	HVAC Control Module Manual																																																											
K	2011	Tahoe	Body	Instrument Panel Cluster																																																											
K	2011	Tahoe	Body	Left Side Object Detection Module																																																											
K	2011	Tahoe	Body	Lift Gate Module																																																											
K	2011	Tahoe	Body	Memory Seat Module																																																											
K	2011	Tahoe	Body	Park Assist Module																																																											
K	2011	Tahoe	Body	Passenger Door Switch																																																											
K	2011	Tahoe	Body	Passenger Presence System																																																											
K	2011	Tahoe	Body	Radio																																																											
K	2011	Tahoe	Body	Rear Heated Seat Module																																																											
K	2011	Tahoe	Body	Rear HVAC/RSA																																																											
K	2011	Tahoe	Body	Right Side Object Detection Module																																																											
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																											
K	2011	Tahoe	Body	Theft Deterrent Module																																																											
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
K	2011	Tahoe Hybrid	Body	Body Control Module																																																											
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																																											
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																																											
K	2011	Tahoe Hybrid	Body	HVAC Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																																											
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																											
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																																											
K	2011	Tahoe Hybrid	Body	Radio																																																											
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2012	Avalanche	Chassis	Electronic Brake Control Module																																																											
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Avalanche	Body	Amplifier (Bose)																																																											
K	2012	Avalanche	Body	Assist Step Controller																																																											
K	2012	Avalanche	Body	Body Control Module																																																											
K	2012	Avalanche	Body	Body Control Module (aux.)																																																											
K	2012	Avalanche	Body	Digital Radio Receiver																																																											
K	2012	Avalanche	Body	Driver Door Switch																																																											
K	2012	Avalanche	Body	HVAC Control Module Auto																																																											
K	2012	Avalanche	Body	HVAC Control Module Manual																																																											
K	2012	Avalanche	Body	Instrument Panel Cluster																																																											
K	2012	Avalanche	Body	Memory Seat Module																																																											
K	2012	Avalanche	Body	Navigation Radio																																																											
K	2012	Avalanche	Body	Park Assist Module																																																											
K	2012	Avalanche	Body	Passenger Door Switch																																																											
K	2012	Avalanche	Body	Passenger Presence System																																																											
K	2012	Avalanche	Body	Radio																																																											
K	2012	Avalanche	Body	Rear Heated Seat Module																																																											
K	2012	Avalanche	Body	Rear HVAC/RSA																																																											
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2012	Avalanche	Body	Theft Deterrent Module																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																												
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
K	2012	Cheyenne	Body	Amplifier (Bose)																																																												
K	2012	Cheyenne	Body	Body Control Module																																																												
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																												
K	2012	Cheyenne	Body	Digital Radio Receiver																																																												
K	2012	Cheyenne	Body	Driver Door Switch																																																												
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																												
K	2012	Cheyenne	Body	Park Assist Module																																																												
K	2012	Cheyenne	Body	Passenger Door Switch																																																												
K	2012	Cheyenne	Body	Passenger Presence System																																																												
K	2012	Cheyenne	Body	Rear Heated Seat Module																																																												
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																												
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																												
K	2012	Cheyenne	Body	Theft Deterrent Module																																																												
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																												V	V	V	V																												
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																												
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2012	Suburban	Chassis	Electronic Suspension Control																																																												
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2012	Suburban	Body	Amplifier (Bose)																																																												
K	2012	Suburban	Body	Assist Step Controller																																																												
K	2012	Suburban	Body	Body Control Module																																																												
K	2012	Suburban	Body	Body Control Module (aux.)																																																												
K	2012	Suburban	Body	Digital Radio Receiver																																																												
K	2012	Suburban	Body	Driver Door Switch																																																												
K	2012	Suburban	Body	HVAC Control Module Auto																																																												
K	2012	Suburban	Body	HVAC Control Module Manual																																																												
K	2012	Suburban	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2012	Suburban	Body	Left Side Object Detection Module																																																											
K	2012	Suburban	Body	Lift Gate Module																																																												
K	2012	Suburban	Body	Memory Seat Module																																																												
K	2012	Suburban	Body	Navigation Radio																																																												
K	2012	Suburban	Body	Park Assist Module																																																												
K	2012	Suburban	Body	Passenger Door Switch																																																												
K	2012	Suburban	Body	Passenger Presence System																																																												
K	2012	Suburban	Body	Radio																																																												
K	2012	Suburban	Body	Rear Heated Seat Module																																																												
K	2012	Suburban	Body	Rear HVAC/RSA																																																												
K	2012	Suburban	Body	Right Side Object Detection Module																																																												
K	2012	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2012	Suburban	Body	Theft Deterrent Module																																																												
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																							V																																				
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V	V	V																																																						
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																						
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																												
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2012	Silverado	Chassis	Electronic Suspension Control																																																											
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
K	2012	Silverado	Body	Amplifier (Bose)																																																											
K	2012	Silverado	Body	Body Control Module																																																											
K	2012	Silverado	Body	Body Control Module (aux.)																																																											
K	2012	Silverado	Body	Digital Radio Receiver																																																											
K	2012	Silverado	Body	Driver Door Switch																																																											
K	2012	Silverado	Body	HVAC Control Module Auto																																																											
K	2012	Silverado	Body	HVAC Control Module Manual																																																											
K	2012	Silverado	Body	Instrument Panel Cluster																																																											
K	2012	Silverado	Body	Memory Seat Module																																																											
K	2012	Silverado	Body	Navigation Radio																																																											
K	2012	Silverado	Body	Park Assist Module																																																											
K	2012	Silverado	Body	Passenger Door Switch																																																											
K	2012	Silverado	Body	Passenger Presence System																																																											
K	2012	Silverado	Body	Radio																																																											
K	2012	Silverado	Body	Rear Heated Seat Module																																																											
K	2012	Silverado	Body	Rear HVAC/RSA																																																											
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																																											
K	2012	Silverado	Body	Theft Deterrent Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																											
K	2012	Silverado Hybrid	Body	Body Control Module																																																											
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																											
K	2012	Silverado Hybrid	Body	Driver Door Switch																																																											
K	2012	Silverado Hybrid	Body	Heated Seat Module																																																											
K	2012	Silverado Hybrid	Body	HVAC Control Module																																																											
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
K	2012	Silverado Hybrid	Body	Navigation Radio																																																											
K	2012	Silverado Hybrid	Body	Park Assist Module																																																											
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																																											
K	2012	Silverado Hybrid	Body	Passenger Presence System																																																											
K	2012	Silverado Hybrid	Body	Radio																																																											
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2012	Tahoe	Chassis	EBCM with Trailer Brake																																																										
K	2012	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Tahoe	Body	Amplifier (Bose)																																																										
K	2012	Tahoe	Body	Assist Step Controller																																																										
K	2012	Tahoe	Body	Body Control Module																																																										
K	2012	Tahoe	Body	Body Control Module (aux.)																																																										
K	2012	Tahoe	Body	Digital Radio Receiver																																																										
K	2012	Tahoe	Body	Driver Door Switch																																																										
K	2012	Tahoe	Body	HVAC Control Module Auto																																																										
K	2012	Tahoe	Body	HVAC Control Module Manual																																																										
K	2012	Tahoe	Body	Instrument Panel Cluster																																																										
K	2012	Tahoe	Body	Left Side Object Detection Module																																																										
K	2012	Tahoe	Body	Lift Gate Module																																																										
K	2012	Tahoe	Body	Memory Seat Module																																																										
K	2012	Tahoe	Body	Navigation Radio																																																										
K	2012	Tahoe	Body	Park Assist Module																																																										
K	2012	Tahoe	Body	Passenger Door Switch																																																										
K	2012	Tahoe	Body	Passenger Presence System																																																										
K	2012	Tahoe	Body	Radio																																																										
K	2012	Tahoe	Body	Rear Heated Seat Module																																																										
K	2012	Tahoe	Body	Rear HVAC/RSA																																																										
K	2012	Tahoe	Body	Right Side Object Detection Module																																																										
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2012	Tahoe	Body	Theft Deterrent Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2012	Tahoe Hybrid	Body	Body Control Module																																																										
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2012	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																										
K	2012	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2012	Tahoe Hybrid	Body	Radio																																																										
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Avalanche	Body	Amplifier (Bose)																																																										
K	2013	Avalanche	Body	Assist Step Controller																																																										
K	2013	Avalanche	Body	Body Control Module																																																										
K	2013	Avalanche	Body	Body Control Module (aux.)																																																										
K	2013	Avalanche	Body	Digital Radio Receiver																																																										
K	2013	Avalanche	Body	Driver Door Switch																																																										
K	2013	Avalanche	Body	HVAC Control Module Auto																																																										
K	2013	Avalanche	Body	HVAC Control Module Manual																																																										
K	2013	Avalanche	Body	Instrument Panel Cluster																																																										
K	2013	Avalanche	Body	Memory Seat Module																																																										
K	2013	Avalanche	Body	Navigation Radio																																																										
K	2013	Avalanche	Body	Park Assist Module																																																										
K	2013	Avalanche	Body	Passenger Door Switch																																																										
K	2013	Avalanche	Body	Passenger Presence System																																																										
K	2013	Avalanche	Body	Radio																																																										
K	2013	Avalanche	Body	Rear Heated Seat Module																																																										
K	2013	Avalanche	Body	Rear HVAC/RSA																																																										
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2013	Avalanche	Body	Theft Deterrent Module																																																										
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Cheyenne	Body	Amplifier (Bose)																																																										
K	2013	Cheyenne	Body	Body Control Module																																																										
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2013	Cheyenne	Body	Digital Radio Receiver																																																										
K	2013	Cheyenne	Body	Driver Door Switch																																																										
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2013	Cheyenne	Body	Park Assist Module																																																										
K	2013	Cheyenne	Body	Passenger Door Switch																																																										
K	2013	Cheyenne	Body	Passenger Presence System																																																										
K	2013	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2013	Cheyenne	Body	Theft Deterrent Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																												V	V	V	V																											
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2013	Suburban	Chassis	Electronic Suspension Control																																																										
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Suburban	Body	Amplifier (Bose)																																																										
K	2013	Suburban	Body	Assist Step Controller																																																										
K	2013	Suburban	Body	Body Control Module																																																										
K	2013	Suburban	Body	Body Control Module (aux.)																																																										
K	2013	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2013	Suburban	Body	Driver Door Switch																																																											
K	2013	Suburban	Body	HVAC Control Module Auto																																																												
K	2013	Suburban	Body	HVAC Control Module Manual																																																												
K	2013	Suburban	Body	Instrument Panel Cluster																																																												
K	2013	Suburban	Body	Left Side Object Detection Module																																																												
K	2013	Suburban	Body	Lift Gate Module																																																												
K	2013	Suburban	Body	Memory Seat Module																																																												
K	2013	Suburban	Body	Navigation Radio																																																												
K	2013	Suburban	Body	Park Assist Module																																																												
K	2013	Suburban	Body	Passenger Door Switch																																																												
K	2013	Suburban	Body	Passenger Presence System																																																												
K	2013	Suburban	Body	Radio																																																											
K	2013	Suburban	Body	Rear Heated Seat Module																																																												
K	2013	Suburban	Body	Rear HVAC/RSA																																																												
K	2013	Suburban	Body	Right Side Object Detection Module																																																												
K	2013	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2013	Suburban	Body	Theft Deterrent Module																																																												
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																							V																																				
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																							V																																				
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																												
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V	V	V																																																						
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2013	Silverado	Chassis	Electronic Suspension Control																																																										
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2013	Silverado	Body	Amplifier (Bose)																																																										
K	2013	Silverado	Body	Body Control Module																																																										
K	2013	Silverado	Body	Body Control Module (aux.)																																																										
K	2013	Silverado	Body	Digital Radio Receiver																																																										
K	2013	Silverado	Body	Driver Door Switch																																																										
K	2013	Silverado	Body	HVAC Control Module Auto																																																										
K	2013	Silverado	Body	HVAC Control Module Manual																																																										
K	2013	Silverado	Body	Instrument Panel Cluster																																																										
K	2013	Silverado	Body	Memory Seat Module																																																										
K	2013	Silverado	Body	Navigation Radio																																																										
K	2013	Silverado	Body	Park Assist Module																																																										
K	2013	Silverado	Body	Passenger Door Switch																																																										
K	2013	Silverado	Body	Passenger Presence System																																																										
K	2013	Silverado	Body	Radio																																																										
K	2013	Silverado	Body	Rear Heated Seat Module																																																										
K	2013	Silverado	Body	Rear HVAC/RSA																																																										
K	2013	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2013	Silverado	Body	Theft Deterrent Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2013	Silverado Hybrid	Body	Body Control Module																																																										
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2013	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2013	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2013	Silverado Hybrid	Body	HVAC Control Module																																																										
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2013	Silverado Hybrid	Body	Navigation Radio																																																										
K	2013	Silverado Hybrid	Body	Park Assist Module																																																										
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2013	Silverado Hybrid	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2013	Silverado Hybrid	Body	Radio																																																										
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																													V	V	V	V																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe	Body	Amplifier (Bose)																																																										
K	2013	Tahoe	Body	Assist Step Controller																																																										
K	2013	Tahoe	Body	Body Control Module																																																										
K	2013	Tahoe	Body	Body Control Module (aux.)																																																										
K	2013	Tahoe	Body	Digital Radio Receiver																																																										
K	2013	Tahoe	Body	Driver Door Switch																																																										
K	2013	Tahoe	Body	HVAC Control Module Auto																																																										
K	2013	Tahoe	Body	HVAC Control Module Manual																																																										
K	2013	Tahoe	Body	Instrument Panel Cluster																																																										
K	2013	Tahoe	Body	Left Side Object Detection Module																																																										
K	2013	Tahoe	Body	Lift Gate Module																																																										
K	2013	Tahoe	Body	Memory Seat Module																																																										
K	2013	Tahoe	Body	Navigation Radio																																																										
K	2013	Tahoe	Body	Park Assist Module																																																										
K	2013	Tahoe	Body	Passenger Door Switch																																																										
K	2013	Tahoe	Body	Passenger Presence System																																																										
K	2013	Tahoe	Body	Radio																																																										
K	2013	Tahoe	Body	Rear Heated Seat Module																																																										
K	2013	Tahoe	Body	Rear HVAC/RSA																																																										
K	2013	Tahoe	Body	Right Side Object Detection Module																																																										
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2013	Tahoe	Body	Theft Deterrent Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
K	2013	Tahoe Hybrid	Body	Body Control Module																																																											
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																											
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																											
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																																											
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																																											
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																											
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																											
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																																											
K	2013	Tahoe Hybrid	Body	Radio																																																											
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																											
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																											
K	2014	Cheyenne	Chassis	Power Steering Control Module																																																											
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2014	Cheyenne	Body	Body Control Module																																																											
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2014	Cheyenne	Body	Passenger Presence Module																																																											
K	2014	Cheyenne	Body	Instrument Cluster																																																											
K	2014	Cheyenne	Body	Radio Control																																																											
K	2014	Cheyenne	Body	HVAC Control																																																											
K	2014	Cheyenne	Body	Radio																																																											
K	2014	Cheyenne	Body	Amplifier																																																											
K	2014	Cheyenne	Body	Media Disc Player																																																											
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																											
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2014	Cheyenne	Body	HVAC Control Module																																																											
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																											
K	2014	Cheyenne	Body	Parking Assist Control Module																																																											
K	2014	Cheyenne	Body	Frontview Camera Module																																																											
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2014	Silverado	Chassis	Electronic Brake Control Module																																																											
K	2014	Silverado	Chassis	Parking Brake Control Module																																																											
K	2014	Silverado	Chassis	Power Steering Control Module																																																											
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2014	Silverado	Body	Body Control Module																																																											
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2014	Silverado	Body	Passenger Presence Module																																																											
K	2014	Silverado	Body	Instrument Cluster																																																											
K	2014	Silverado	Body	Radio Control																																																										
K	2014	Silverado	Body	HVAC Control																																																										
K	2014	Silverado	Body	Radio																																																										
K	2014	Silverado	Body	Amplifier																																																										
K	2014	Silverado	Body	Media Disc Player																																																										
K	2014	Silverado	Body	Human Machine Interface Control Module																																																											
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																											
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
K	2014	Silverado	Body	Parking Assist Control Module																																																											
K	2014	Silverado	Body	Frontview Camera Module																																																											
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																															
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																											
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																											
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2014	Silverado HD	Chassis	Suspension Control Module																																																										
K	2014	Silverado HD	Body	Body Control Module																																																											
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2014	Silverado HD	Body	Passenger Presence Module																																																											
K	2014	Silverado HD	Body	Instrument Cluster																																																											
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																											
K	2014	Silverado HD	Body	Base Radio																																																											
K	2014	Silverado HD	Body	Navigation Radio																																																											
K	2014	Silverado HD	Body	Uplevel Radio																																																											
K	2014	Silverado HD	Body	Amplifier																																																											
K	2014	Silverado HD	Body	Rear Audio Control Module																																																											
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																											
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																											
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																											
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																										V																
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																										V																
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																										V																
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																										V																
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Silverado HD	Body	Seat Memory Control Module																																																										
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																										
K	2014	Silverado HD	Body	Parking Assist Control Module																																																										
K	2014	Silverado HD	Body	Theft Deterrent Module																																																										
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																										
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2014	Suburban	Chassis	Parking Brake Control Module																																																										
K	2014	Suburban	Chassis	Suspension Control Module																																																										
K	2014	Suburban	Body	Body Control Module																																																										
K	2014	Suburban	Body	Auxiliary Body Control Module																																																										
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Suburban	Body	Passenger Presence Module																																																										
K	2014	Suburban	Body	Instrument Cluster																																																										
K	2014	Suburban	Body	Base Radio																																																										
K	2014	Suburban	Body	Navigation Radio																																																										
K	2014	Suburban	Body	Uplevel Radio																																																										
K	2014	Suburban	Body	Amplifier																																																										
K	2014	Suburban	Body	Rear Audio Control Module																																																										
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																										
K	2014	Suburban	Body	Personal Audio Link Control Module																																																										
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																									V															
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																									V															
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																							
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																							
K	2014	Suburban	Body	Liftgate Control Module																																																							
K	2014	Suburban	Body	Seat Memory Control Module																																																						
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																						
K	2014	Suburban	Body	Assist Step Control Module																																																						
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																						
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																						
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																						
K	2014	Suburban	Body	Parking Assist Control Module																																																						
K	2014	Suburban	Body	Theft Deterrent Module																																																						
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																						
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																						
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																						
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																						
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																						
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																						
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																						
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																						
K	2014	Tahoe	Chassis	Suspension Control Module																																																						
K	2014	Tahoe	Body	Body Control Module																																																						
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																						
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
K	2014	Tahoe	Body	Passenger Presence Module																																																						
K	2014	Tahoe	Body	Instrument Cluster																																																						
K	2014	Tahoe	Body	Base Radio																																																						
K	2014	Tahoe	Body	Navigation Radio																																																						
K	2014	Tahoe	Body	Uplevel Radio																																																						
K	2014	Tahoe	Body	Amplifier																																																						
K	2014	Tahoe	Body	Rear Audio Control Module																																																						
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																						
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																						
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																						
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																						
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																									V															
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																									V															
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																						
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																						
K	2014	Tahoe	Body	Liftgate Control Module																																																						
K	2014	Tahoe	Body	Seat Memory Control Module																																																						
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																						
K	2014	Tahoe	Body	Assist Step Control Module																																																						
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																						
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																						
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																						
K	2014	Tahoe	Body	Parking Assist Control Module																																																						
K	2014	Tahoe	Body	Theft Deterrent Module																																																						
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																						
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																						

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																												
K	2015	Cheyenne	Chassis	Power Steering Control Module																																																												
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Cheyenne	Chassis	Suspension Control Module																																																												
K	2015	Cheyenne	Body	Body Control Module																																																												
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Cheyenne	Body	Passenger Presence Module																																																												
K	2015	Cheyenne	Body	Instrument Cluster																																																												
K	2015	Cheyenne	Body	Radio Controls																																																												
K	2015	Cheyenne	Body	HVAC Controls																																																												
K	2015	Cheyenne	Body	Radio																																																												
K	2015	Cheyenne	Body	Amplifier																																																												
K	2015	Cheyenne	Body	Media Disc Player																																																												
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																												
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																												
K	2015	Cheyenne	Body	HVAC Control Module																																																												
K	2015	Cheyenne	Body	Parking Assist Control Module																																																												
K	2015	Cheyenne	Body	Frontview Camera Module																																																												
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																											
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2015	Silverado	Chassis	Electronic Brake Control Module																																																											
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																											
K	2015	Silverado	Chassis	Power Steering Control Module																																																											
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Silverado	Chassis	Suspension Control Module																																																											
K	2015	Silverado	Body	Body Control Module																																																											
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Silverado	Body	Passenger Presence Module																																																											
K	2015	Silverado	Body	Instrument Cluster																																																											
K	2015	Silverado	Body	Radio Controls																																																											
K	2015	Silverado	Body	HVAC Controls																																																											
K	2015	Silverado	Body	Radio																																																											
K	2015	Silverado	Body	Amplifier																																																											
K	2015	Silverado	Body	Media Disc Player																																																											
K	2015	Silverado	Body	Human Machine Interface Control Module																																																											
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																																											
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
K	2015	Silverado	Body	Parking Assist Control Module																																																											
K	2015	Silverado	Body	Frontview Camera Module																																																											
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																											
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2015	Suburban	Chassis	Electronic Brake Control Module																																																											
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																											
K	2015	Suburban	Chassis	Parking Brake Control Module																																																											
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																											
K	2015	Suburban	Chassis	Power Steering Control Module																																																											
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Suburban	Chassis	Suspension Control Module																																																											
K	2015	Suburban	Body	Body Control Module																																																											
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Suburban	Body	Passenger Presence Module																																																											
K	2015	Suburban	Body	Instrument Cluster																																																											
K	2015	Suburban	Body	Radio Controls																																																											
K	2015	Suburban	Body	HVAC Controls																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2015	Suburban	Body	Radio																																																											
K	2015	Suburban	Body	Amplifier																																																											
K	2015	Suburban	Body	Media Disc Player																																																											
K	2015	Suburban	Body	Human Machine Interface Control Module																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2015	Suburban	Body	HVAC Control Module																																																											
K	2015	Suburban	Body	Liftgate Control Module																																																											
K	2015	Suburban	Body	Keyless Entry Control Module																																																											
K	2015	Suburban	Body	Assist Step Control Module																																																											
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																											
K	2015	Suburban	Body	Parking Assist Control Module																																																											
K	2015	Suburban	Body	Frontview Camera Module																																																											
K	2015	Suburban	Body	Steering Column Lock Control Module																																																											
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																											
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																											
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																											
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																											
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																											
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																											
K	2015	Tahoe	Chassis	Power Steering Control Module																																																											
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Tahoe	Chassis	Suspension Control Module																																																											
K	2015	Tahoe	Body	Body Control Module																																																											
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Tahoe	Body	Passenger Presence Module																																																											
K	2015	Tahoe	Body	Instrument Cluster																																																											
K	2015	Tahoe	Body	Radio Controls																																																											
K	2015	Tahoe	Body	HVAC Controls																																																											
K	2015	Tahoe	Body	Radio																																																										
K	2015	Tahoe	Body	Amplifier																																																										
K	2015	Tahoe	Body	Media Disc Player																																																											
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2015	Tahoe	Body	HVAC Control Module																																																											
K	2015	Tahoe	Body	Liftgate Control Module																																																											
K	2015	Tahoe	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2015	Tahoe	Body	Assist Step Control Module																																																										
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2015	Tahoe	Body	Parking Assist Control Module																																																										
K	2015	Tahoe	Body	Frontview Camera Module																																																										
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																										
K	2015	Tahoe	Body	Battery Energy Control Module																																																										
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																										
K	2016	Cheyenne	Chassis	Power Steering Control Module																																																										
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Cheyenne	Chassis	Suspension Control Module																																																										
K	2016	Cheyenne	Body	Body Control Module																																																										
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Cheyenne	Body	Passenger Presence Module																																																										
K	2016	Cheyenne	Body	Instrument Cluster																																																										
K	2016	Cheyenne	Body	Radio Controls																																																										
K	2016	Cheyenne	Body	HVAC Controls																																																										
K	2016	Cheyenne	Body	Radio																																																										
K	2016	Cheyenne	Body	Amplifier																																																										
K	2016	Cheyenne	Body	Media Disc Player																																																										
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																										
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
K	2016	Cheyenne	Body	HVAC Control Module																																																										
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																										
K	2016	Cheyenne	Body	Parking Assist Control Module																																																										
K	2016	Cheyenne	Body	Frontview Camera Module																																																										
K	2016	Cheyenne	Body	Frontview Camera Module																																																										
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2016	Silverado	Chassis	Electronic Brake Control Module																																																												
K	2016	Silverado	Chassis	Power Steering Control Module																																																												
K	2016	Silverado	Chassis	Power Steering Control Module																																																												
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2016	Silverado	Chassis	Suspension Control Module																																																												
K	2016	Silverado	Body	Body Control Module																																																												
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2016	Silverado	Body	Passenger Presence Module																																																												
K	2016	Silverado	Body	Instrument Cluster																																																												
K	2016	Silverado	Body	Radio Controls																																																											
K	2016	Silverado	Body	HVAC Controls																																																											
K	2016	Silverado	Body	Radio (IO3)																																																											
K	2016	Silverado	Body	Radio (IOB)																																																											
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																											
K	2016	Silverado	Body	Amplifier																																																											
K	2016	Silverado	Body	Media Disc Player																																																											
K	2016	Silverado	Body	Human Machine Interface Control Module																																																											
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																											
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																											
K	2016	Silverado	Body	Parking Assist Control Module																																																											
K	2016	Silverado	Body	Frontview Camera Module																																																											
K	2016	Silverado	Body	Frontview Camera Module																																																											
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2016	Suburban	Chassis	Electronic Brake Control Module																																																											
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																											
K	2016	Suburban	Chassis	Parking Brake Control Module																																																											
K	2016	Suburban	Chassis	Power Steering Control Module																																																											
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2016	Suburban	Chassis	Suspension Control Module																																																											
K	2016	Suburban	Body	Body Control Module																																																											
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2016	Suburban	Body	Passenger Presence Module																																																											
K	2016	Suburban	Body	Instrument Cluster																																																												
K	2016	Suburban	Body	Radio Controls																																																												
K	2016	Suburban	Body	HVAC Controls																																																												
K	2016	Suburban	Body	Radio																																																												
K	2016	Suburban	Body	Amplifier																																																												
K	2016	Suburban	Body	Media Disc Player																																																												
K	2016	Suburban	Body	Human Machine Interface Control Module																																																												
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																																												
K	2016	Suburban	Body	HVAC Control Module																																																												
K	2016	Suburban	Body	Liftgate Control Module																																																												
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																												
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																												
K	2016	Suburban	Body	Keyless Entry Control Module																																																												
K	2016	Suburban	Body	Assist Step Control Module																																																												
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																												
K	2016	Suburban	Body	Parking Assist Control Module																																																												
K	2016	Suburban	Body	Frontview Camera Module																																																												
K	2016	Suburban	Body	Steering Column Lock Control Module																																																												
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																												
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																												
K	2016	Tahoe	Chassis	Power Steering Control Module																																																												
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2016	Tahoe	Chassis	Suspension Control Module																																																												
K	2016	Tahoe	Body	Body Control Module																																																												
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2016	Tahoe	Body	Passenger Presence Module																																																												
K	2016	Tahoe	Body	Instrument Cluster																																																												
K	2016	Tahoe	Body	Radio Controls																																																												
K	2016	Tahoe	Body	HVAC Controls																																																												
K	2016	Tahoe	Body	Radio																																																												
K	2016	Tahoe	Body	Amplifier																																																												
K	2016	Tahoe	Body	Media Disc Player																																																												
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																												
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																												
K	2016	Tahoe	Body	HVAC Control Module																																																												
K	2016	Tahoe	Body	Liftgate Control Module																																																												
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																												
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																												
K	2016	Tahoe	Body	Keyless Entry Control Module																																																												
K	2016	Tahoe	Body	Assist Step Control Module																																																												
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																												
K	2016	Tahoe	Body	Parking Assist Control Module																																																												
K	2016	Tahoe	Body	Frontview Camera Module																																																												
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
L	2004	ALL	Chassis	4WAL 3 Sensor																																																												
L	2004	ALL	Body	Body Control Module																																																											
L	2004	ALL	Body	Instrument Panel Cluster																																																											
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
L	2005	Astro	Chassis	4WAL 3 Sensor																																																											
L	2005	Astro	Body	Body Control Module																																																										
L	2005	Astro	Body	Instrument Panel Cluster																																																										
L	2005	Astro	Body	Supplemental Inflatable Restraint																																																										
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																								V																	
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																																										
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																																										
L	2005	Equinox	Chassis	Electric Power Steering																																																										
L	2005	Equinox	Body	Body Control Module																																																										
L	2005	Equinox	Body	Instrument Panel Cluster																																																										
L	2005	Equinox	Body	Radio																																																										
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																								V																	
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2006	ALL	Chassis	Traction Control Yes																																																										
L	2006	ALL	Chassis	Traction Control No																																																										
L	2006	ALL	Chassis	Electric Power Steering																																																										
L	2006	ALL	Body	Body Control Module																																																										
L	2006	ALL	Body	Instrument Panel Cluster																																																										
L	2006	ALL	Body	Radio																																																										
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																																										
L	2007	ALL	Chassis	Power Steering Control Module																																																										
L	2007	ALL	Body	Body Control Module																																																										
L	2007	ALL	Body	Digital Radio Receiver																																																										
L	2007	ALL	Body	Heated Seat Module																																																										
L	2007	ALL	Body	HVAC Control Module																																																										
L	2007	ALL	Body	Instrument Panel Cluster																																																										
L	2007	ALL	Body	Passenger Presence System																																																										
L	2007	ALL	Body	Radio																																																										
L	2007	ALL	Body	Rollover Sensor																																																										
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Body	Theft Deterrent Module																																																										
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																																												
L	2008	Captiva Sport	Body	Body Control Module																																																												
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																												
L	2008	Captiva Sport	Body	HVAC Control Module Auto																																																												
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																																												
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																																												
L	2008	Captiva Sport	Body	Passenger Presence System																																																												
L	2008	Captiva Sport	Body	Radio																																																												
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2008	Captiva Sport	Body	Rollover Sensor																																																												
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																																												
L	2008	Captiva Sport	Body	Theft Deterrent Module																																																												
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																												
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																												
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																												
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																												
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
L	2008	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2008	Equinox	Chassis	Power Steering Control Module																																																												
L	2008	Equinox	Body	Body Control Module																																																												
L	2008	Equinox	Body	Digital Radio Receiver																																																												
L	2008	Equinox	Body	Heated Seat Module																																																												
L	2008	Equinox	Body	HVAC Control Module																																																												
L	2008	Equinox	Body	Instrument Panel Cluster																																																												
L	2008	Equinox	Body	Passenger Presence System																																																												
L	2008	Equinox	Body	Radio																																																												
L	2008	Equinox	Body	Rollover Sensor																																																												
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																																												
L	2008	Equinox	Body	Theft Deterrent Module																																																												
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																												
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																												
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																												
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																												
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																												
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																																												
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																												
L	2009	Captiva Sport	Body	Body Control Module																																																												
L	2009	Captiva Sport	Body	HVAC Control Module Auto																																																												
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																																												
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																																												
L	2009	Captiva Sport	Body	Passenger Presence System																																																												
L	2009	Captiva Sport	Body	Radio																																																												
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2009	Captiva Sport	Body	Rollover Sensor																																																												
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																																												
L	2009	Captiva Sport	Body	Theft Deterrent Module																																																												
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																											
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																												
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																												
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
L	2009	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2009	Equinox	Chassis	Power Steering Control Module																																																												
L	2009	Equinox	Body	Body Control Module																																																												
L	2009	Equinox	Body	Digital Radio Receiver																																																												
L	2009	Equinox	Body	Heated Seat Module																																																												
L	2009	Equinox	Body	HVAC Control Module																																																												
L	2009	Equinox	Body	Instrument Panel Cluster																																																												
L	2009	Equinox	Body	Passenger Presence System																																																												
L	2009	Equinox	Body	Radio																																																												
L	2009	Equinox	Body	Rollover Sensor																																																												
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																																												
L	2009	Equinox	Body	Theft Deterrent Module																																																												
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																												
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																												
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																												
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																												
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																												
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																												
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																												
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																												
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																																												
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																												
L	2010	Captiva Sport	Body	Body Control Module																																																												
L	2010	Captiva Sport	Body	HVAC Control Module																																																												
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																																												
L	2010	Captiva Sport	Body	Passenger Presence System																																																												
L	2010	Captiva Sport	Body	Radio																																																												
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2010	Captiva Sport	Body	Rollover Sensor																																																												
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																																												
L	2010	Captiva Sport	Body	Theft Deterrent Module																																																												
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																												
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																												
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																												
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																												
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2010	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2010	Equinox	Body	Body Control Module																																																											
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2010	Equinox	Body	Passenger Presence Module																																																											
L	2010	Equinox	Body	Instrument Cluster																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2010	Equinox	Body	Radio																																																											
L	2010	Equinox	Body	Multimedia Player Interface Module																																																											
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											
L	2010	Equinox	Body	Liftgate Control Module																																																											
L	2010	Equinox	Body	Parking Assist Control Module																																																											
L	2010	Equinox	Body	Frontview Camera Module																																																											
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																																											
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																											
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																											
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																											
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																											
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																											
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																											
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																											
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																											
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																											
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																											
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																											
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																											
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
L	2011	Captiva	Chassis	Electronic Brake Control Module																																																											
L	2011	Captiva	Chassis	Parking Brake Control Module																																																											
L	2011	Captiva	Body	Body Control Module																																																											
L	2011	Captiva	Body	Auxiliary Body Control Module																																																											
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2011	Captiva	Body	Instrument Cluster																																																											
L	2011	Captiva	Body	Headlamp Control Module																																																											
L	2011	Captiva	Body	HVAC Control Module																																																											
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																											
L	2011	Captiva	Body	Parking Assist Control Module																																																											
L	2011	Captiva	Body	Theft Deterrent Module																																																											
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module																																																											
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																											
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																											
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																																											
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module																																																											
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																											
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																											
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																											
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																											
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																											
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																											
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																																										
L	2011	Captiva Sport	Body	Body Control Module																																																										
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2011	Captiva Sport	Body	HVAC Control Module																																																										
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2011	Captiva Sport	Body	Passenger Presence System																																																										
L	2011	Captiva Sport	Body	Radio																																																										
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2011	Captiva Sport	Body	Rollover Sensor																																																										
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2011	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																																										
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																										
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																										
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2011	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2011	Equinox	Body	Body Control Module																																																										
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2011	Equinox	Body	Passenger Presence Module																																																										
L	2011	Equinox	Body	Instrument Cluster																																																										
L	2011	Equinox	Body	Radio																																																										
L	2011	Equinox	Body	Multimedia Player Interface Module																																																										
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2011	Equinox	Body	Liftgate Control Module																																																										
L	2011	Equinox	Body	Parking Assist Control Module																																																										
L	2011	Equinox	Body	Frontview Camera Module																																																										
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																																																										
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
L	2012	Captiva	Chassis	Electronic Brake Control Module																																																											
L	2012	Captiva	Chassis	Parking Brake Control Module																																																											
L	2012	Captiva	Body	Body Control Module																																																											
L	2012	Captiva	Body	Auxiliary Body Control Module																																																											
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2012	Captiva	Body	Instrument Cluster																																																											
L	2012	Captiva	Body	Headlamp Control Module																																																											
L	2012	Captiva	Body	HVAC Control Module																																																											
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																											
L	2012	Captiva	Body	Parking Assist Control Module																																																											
L	2012	Captiva	Body	Theft Deterrent Module																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																										V	V																																
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																										V	V																																
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module																																																											
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																																											
L	2012	Captiva Sport	Body	Body Control Module																																																											
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																											
L	2012	Captiva Sport	Body	HVAC Control Module																																																											
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																																											
L	2012	Captiva Sport	Body	Passenger Presence System																																																											
L	2012	Captiva Sport	Body	Radio																																																											
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																																											
L	2012	Captiva Sport	Body	Rollover Sensor																																																											
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																																																											
L	2012	Captiva Sport	Body	Theft Deterrent Module																																																											
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																											
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																											
L	2012	Equinox	Chassis	Electronic Brake Control Module																																																											
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2012	Equinox	Body	Body Control Module																																																											
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2012	Equinox	Body	Passenger Presence Module																																																											
L	2012	Equinox	Body	Instrument Cluster																																																											
L	2012	Equinox	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2012	Equinox	Body	Multimedia Player Interface Module																																																										
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2012	Equinox	Body	Liftgate Control Module																																																										
L	2012	Equinox	Body	Parking Assist Control Module																																																										
L	2012	Equinox	Body	Frontview Camera Module																																																										
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																																										
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																										
L	2013	Captiva	Chassis	Parking Brake Control Module																																																										
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																										
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																										
L	2013	Captiva	Body	Auxiliary Body Control Module																																																										
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2013	Captiva	Body	Instrument Cluster																																																										
L	2013	Captiva	Body	Headlamp Control Module																																																										
L	2013	Captiva	Body	HVAC Control Module																																																										
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2013	Captiva	Body	Theft Deterrent Module																																																										
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																										
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																										
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																											V	V																														
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																										
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																										
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																											V	V																														
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																										
L	2013	Captiva Sport	Body	Body Control Module																																																										
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2013	Captiva Sport	Body	Heated Seat Module																																																										
L	2013	Captiva Sport	Body	HVAC Control Module																																																										
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2013	Captiva Sport	Body	Park Assist Module																																																											
L	2013	Captiva Sport	Body	Passenger Presence System																																																											
L	2013	Captiva Sport	Body	Radio																																																										
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																										
L	2013	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2013	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2013	Equinox	Chassis	Power Steering Control Module																																																										
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2013	Equinox	Body	Passenger Presence Module																																																										
L	2013	Equinox	Body	Instrument Cluster																																																										
L	2013	Equinox	Body	Radio																																																										
L	2013	Equinox	Body	Rear Audio Control Module																																																										
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2013	Equinox	Body	Liftgate Control Module																																																										
L	2013	Equinox	Body	Front Seat Heating Control Module																																																										
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2013	Equinox	Body	Parking Assist Control Module																																																										
L	2013	Equinox	Body	Frontview Camera Module																																																										
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2014	Captiva (3GN)	Body	Body Control Module																																																										
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																										
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2014	Captiva (3GN)	Body	Radio																																																										
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																										
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																											
L	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																											
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																											
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																											
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																											
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2014	Captiva (Other)	Body	Instrument Cluster																																																											
L	2014	Captiva (Other)	Body	Headlamp Control Module																																																											
L	2014	Captiva (Other)	Body	HVAC Control Module																																																											
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
L	2014	Captiva (Other)	Body	Theft Deterrent Module																																																											
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																											
L	2014	Equinox	Chassis	Electronic Brake Control Module																																																											
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2014	Equinox	Chassis	Power Steering Control Module																																																											
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																											
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2014	Equinox	Body	Passenger Presence Module																																																											
L	2014	Equinox	Body	Instrument Cluster																																																											
L	2014	Equinox	Body	Radio																																																											
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2014	Equinox	Body	Liftgate Control Module																																																										
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2014	Equinox	Body	Parking Assist Control Module																																																										
L	2014	Equinox	Body	Frontview Camera Module																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (3GN)	Body	Body Control Module																																																										
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																																										
L	2015	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2015	Captiva (3GN)	Body	Radio																																																										
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
L	2015	Captiva (3GN)	Body	HVAC Control Module																																																										
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Captiva (Other)	Body	Instrument Cluster																																																										
L	2015	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2015	Captiva (Other)	Body	HVAC Control Module																																																										
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2015	Captiva (Other)	Body	Theft Deterrent Module																																																											
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																											
L	2015	Equinox	Chassis	Electronic Brake Control Module																																																											
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2015	Equinox	Chassis	Power Steering Control Module																																																											
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																																											
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2015	Equinox	Body	Passenger Presence Module																																																											
L	2015	Equinox	Body	Instrument Cluster																																																											
L	2015	Equinox	Body	Radio																																																											
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																																											
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											
L	2015	Equinox	Body	Liftgate Control Module																																																											
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																											
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																											
L	2015	Equinox	Body	Parking Assist Control Module																																																											
L	2015	Equinox	Body	Frontview Camera Module																																																											
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																											
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																											
L	2016	Captiva (3GN)	Body	Body Control Module																																																											
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2016	Captiva (3GN)	Body	Instrument Cluster																																																											
L	2016	Captiva (3GN)	Body	Radio																																																											
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																											
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																											
L	2016	Captiva (3GN)	Body	HVAC Control Module																																																											
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																											
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																											
L	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission	V					V	V	V	V	V																																																	
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission	V					V	V	V	V	V																																																	
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Captiva (Other)	Body	Instrument Cluster																																																										
L	2016	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2016	Captiva (Other)	Body	Radio																																																										
L	2016	Captiva (Other)	Body	HVAC Control Module																																																										
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2016	Captiva (Other)	Body	Theft Deterrent Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2016	Equinox	Chassis	Power Steering Control Module																																																										
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Equinox	Body	Passenger Presence Module																																																										
L	2016	Equinox	Body	Instrument Cluster																																																										
L	2016	Equinox	Body	Radio																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2016	Equinox	Body	Liftgate Control Module																																																										
L	2016	Equinox	Body	Seat Memory Control Module																																																										
L	2016	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Parking Assist Control Module																																																										
L	2016	Equinox	Body	Frontview Camera Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
M	2004	ALL	Chassis	4WAL 3 Sensor																																																											
M	2004	ALL	Body	Body Control Module																																																											
M	2004	ALL	Body	Instrument Panel Cluster																																																											
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
M	2005	ALL	Chassis	4WAL 3 Sensor																																																											
M	2005	ALL	Body	Body Control Module																																																										
M	2005	ALL	Body	Instrument Panel Cluster																																																										
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
P	2007	ALL	Body	Theft Deterrent Module																																																										
R	2009	ALL	Powertrain	Engine Control Module																																																										
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2009	ALL	Powertrain	Transmission Control Module																																																										
R	2009	ALL	Chassis	Electronic Brake Control Module																																																										
R	2009	ALL	Body	Body Control Module																																																										
R	2009	ALL	Body	Digital Radio Receiver																																																										
R	2009	ALL	Body	Driver Door Switch																																																										
R	2009	ALL	Body	Heated Seat Module																																																										
R	2009	ALL	Body	HVAC Control Module Auto																																																										
R	2009	ALL	Body	HVAC Control Module Manual																																																										
R	2009	ALL	Body	Instrument Panel Cluster																																																										
R	2009	ALL	Body	Lift Gate Module																																																										
R	2009	ALL	Body	Park Assist Module																																																										
R	2009	ALL	Body	Passenger Door Switch																																																										
R	2009	ALL	Body	Passenger Presence System																																																										
R	2009	ALL	Body	Radio																																																										
R	2009	ALL	Body	Rear HVAC/RSA																																																										
R	2009	ALL	Body	Rollover Sensor																																																										
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2009	ALL	Body	Theft Deterrent Module																																																										
R	2010	ALL	Powertrain	Engine Control Module																																																										
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2010	ALL	Powertrain	Transmission Control Module																																																										
R	2010	ALL	Chassis	Electronic Brake Control Module																																																										
R	2010	ALL	Body	Body Control Module																																																										
R	2010	ALL	Body	Digital Radio Receiver																																																										
R	2010	ALL	Body	Driver Door Switch																																																										
R	2010	ALL	Body	Heated Seat Module																																																										
R	2010	ALL	Body	HVAC Control Module Auto																																																										
R	2010	ALL	Body	HVAC Control Module Manual																																																										
R	2010	ALL	Body	Instrument Panel Cluster																																																										
R	2010	ALL	Body	Lift Gate Module																																																										
R	2010	ALL	Body	Park Assist Module																																																										
R	2010	ALL	Body	Passenger Door Switch																																																										
R	2010	ALL	Body	Passenger Presence System																																																										
R	2010	ALL	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2010	ALL	Body	Rear HVAC/RSA																																																											
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2010	ALL	Body	Theft Deterrent Module																																																												
R	2011	ALL	Powertrain	Engine Control Module																																																												
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2011	ALL	Powertrain	Transmission Control Module																																																												
R	2011	ALL	Chassis	Electronic Brake Control Module																																																												
R	2011	ALL	Body	Body Control Module																																																												
R	2011	ALL	Body	Digital Radio Receiver																																																												
R	2011	ALL	Body	Driver Door Switch																																																												
R	2011	ALL	Body	Heated Seat Module																																																												
R	2011	ALL	Body	HVAC Control Module Auto																																																												
R	2011	ALL	Body	HVAC Control Module Manual																																																												
R	2011	ALL	Body	Instrument Panel Cluster																																																												
R	2011	ALL	Body	Lift Gate Module																																																												
R	2011	ALL	Body	Park Assist Module																																																												
R	2011	ALL	Body	Passenger Door Switch																																																												
R	2011	ALL	Body	Passenger Presence System																																																												
R	2011	ALL	Body	Radio																																																												
R	2011	ALL	Body	Rear HVAC/RSA																																																												
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2011	ALL	Body	Theft Deterrent Module																																																												
R	2012	ALL	Powertrain	Engine Control Module																																																												
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2012	ALL	Powertrain	Transmission Control Module																																																												
R	2012	ALL	Chassis	Electronic Brake Control Module																																																												
R	2012	ALL	Body	Body Control Module																																																												
R	2012	ALL	Body	Digital Radio Receiver																																																												
R	2012	ALL	Body	Driver Door Switch																																																												
R	2012	ALL	Body	Heated Seat Module																																																												
R	2012	ALL	Body	HVAC Control Module Auto																																																												
R	2012	ALL	Body	HVAC Control Module Manual																																																												
R	2012	ALL	Body	Instrument Panel Cluster																																																												
R	2012	ALL	Body	Lift Gate Module																																																												
R	2012	ALL	Body	Park Assist Module																																																												
R	2012	ALL	Body	Passenger Door Switch																																																												
R	2012	ALL	Body	Passenger Presence System																																																												
R	2012	ALL	Body	Radio																																																												
R	2012	ALL	Body	Rear HVAC/RSA																																																												
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2012	ALL	Body	Theft Deterrent Module																																																												
R	2013	ALL	Powertrain	Engine Control Module																																																												
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2013	ALL	Powertrain	Transmission Control Module																																																												
R	2013	ALL	Chassis	Electronic Brake Control Module																																																												
R	2013	ALL	Body	Body Control Module																																																												
R	2013	ALL	Body	Digital Radio Receiver																																																												
R	2013	ALL	Body	Driver Door Switch																																																												
R	2013	ALL	Body	Heated Seat Module																																																												
R	2013	ALL	Body	HVAC Control Module Auto																																																												
R	2013	ALL	Body	HVAC Control Module Manual																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2013	ALL	Body	Instrument Panel Cluster																																																											
R	2013	ALL	Body	Left Side Object Detection Module																																																												
R	2013	ALL	Body	Lift Gate Module																																																												
R	2013	ALL	Body	Park Assist Module																																																												
R	2013	ALL	Body	Passenger Door Switch																																																												
R	2013	ALL	Body	Passenger Presence System																																																												
R	2013	ALL	Body	Radio																																																												
R	2013	ALL	Body	Rear HVAC/RSA																																																												
R	2013	ALL	Body	Right Side Object Detection Module																																																												
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2013	ALL	Body	Theft Deterrent Module																																																												
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2014	Traverse	Powertrain	Chassis Control Module																																																												
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
R	2014	Traverse	Chassis	Electronic Brake Control Module																																																												
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																												
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Traverse	Body	Passenger Presence Module																																																												
R	2014	Traverse	Body	Instrument Cluster																																																												
R	2014	Traverse	Body	Radio																																																												
R	2014	Traverse	Body	Rear Audio Control Module																																																												
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																												
R	2014	Traverse	Body	Personal Audio Link Control Module																																																												
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																										V																	
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																										V																	
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																												
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																												
R	2014	Traverse	Body	Liftgate Control Module																																																												
R	2014	Traverse	Body	Seat Memory Control Module																																																												
R	2014	Traverse	Body	Front Seat Heating Control Module																																																												
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																												
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																												
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																												
R	2014	Traverse	Body	Parking Assist Control Module																																																												
R	2014	Traverse	Body	Frontview Camera Module																																																												
R	2014	Traverse	Body	Theft Deterrent Module																																																												
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
R	2015	Traverse	Chassis	Electronic Brake Control Module																																																												
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																												
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Traverse	Body	Passenger Presence Module																																																												
R	2015	Traverse	Body	Instrument Cluster																																																												
R	2015	Traverse	Body	Radio																																																												
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																									
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																									
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																									V															
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																									V															
R	2015	Traverse	Body	Liftgate Control Module																																																								
R	2015	Traverse	Body	Seat Memory Control Module																																																								
R	2015	Traverse	Body	Front Seat Heating Control Module																																																								
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																								
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																								
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																								
R	2015	Traverse	Body	Parking Assist Control Module																																																								
R	2015	Traverse	Body	Frontview Camera Module																																																								
R	2015	Traverse	Body	Theft Deterrent Module																																																								
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																								
R	2016	Traverse	Chassis	Electronic Brake Control Module																																																								
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																								
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																								
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2016	Traverse	Body	Passenger Presence Module																																																								
R	2016	Traverse	Body	Instrument Cluster																																																								
R	2016	Traverse	Body	Radio																																																								
R	2016	Traverse	Body	Rear Audio Control Module																																																								
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																								
R	2016	Traverse	Body	Personal Audio Link Control Module																																																								
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																								
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																									V															
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																									V															
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																								
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																								
R	2016	Traverse	Body	Liftgate Control Module																																																								
R	2016	Traverse	Body	Seat Memory Control Module																																																								
R	2016	Traverse	Body	Front Seat Heating Control Module																																																								
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																								
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																								
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																								
R	2016	Traverse	Body	Parking Assist Control Module																																																								
R	2016	Traverse	Body	Frontview Camera Module																																																								
R	2016	Traverse	Body	Theft Deterrent Module																																																								
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
S	2004	S10	Chassis	4WAL 3 Sensor																																																								
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																								
S	2004	S10	Body	Body Control Module																																																								
S	2004	S10	Body	Instrument Panel Cluster																																																								
S	2004	S10	Body	Base Radio																																																								
S	2004	S10	Body	Uplevel Radio																																																								
S	2004	S10	Body	Supplemental Inflatable Restraint																																																								
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																								
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2004	Colorado	Chassis	ABS Without Traction Control																																																												
S	2004	Colorado	Chassis	ABS With Traction Control																																																												
S	2004	Colorado	Body	Body Control Module																																																												
S	2004	Colorado	Body	Instrument Panel Cluster																																																												
S	2004	Colorado	Body	OnStar																																																												
S	2004	Colorado	Body	Base Radio																																																												
S	2004	Colorado	Body	Uplevel Radio																																																												
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																												
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																												
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																												
S	2004	TrailBlazer	Body	Body Control Module																																																												
S	2004	TrailBlazer	Body	Driver Door Module																																																												
S	2004	TrailBlazer	Body	Driver Seat Module																																																												
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																												
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																												
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2004	TrailBlazer	Body	Lift Gate Module																																																												
S	2004	TrailBlazer	Body	OnStar																																																												
S	2004	TrailBlazer	Body	Passenger Door Module																																																												
S	2004	TrailBlazer	Body	Uplevel Radio																																																												
S	2004	TrailBlazer	Body	Navigation Radio																																																												
S	2004	TrailBlazer	Body	Rear Seat Audio																																																												
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																												
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																												
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																												
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																												
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																												
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																												
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																												
S	2004	TrailBlazer EXT	Body	Body Control Module																																																												
S	2004	TrailBlazer EXT	Body	Driver Door Module																																																												
S	2004	TrailBlazer EXT	Body	Driver Seat Module																																																												
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																												
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																												
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																												
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																												
S	2004	TrailBlazer EXT	Body	OnStar																																																												
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																																												
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																												
S	2004	TrailBlazer EXT	Body	Navigation Radio																																																												
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																										
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																										
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Blazer	Body	Body Control Module																																																										
S	2004	Blazer	Body	Heating and Air Conditioning																																																										
S	2004	Blazer	Body	Instrument Panel Cluster																																																										
S	2004	Blazer	Body	Memory Seat Module																																																										
S	2004	Blazer	Body	Base Radio																																																										
S	2004	Blazer	Body	Uplevel Radio																																																										
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																																										
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	SSR	Chassis	4WAL 3 Sensor																																																										
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																										
S	2004	SSR	Body	Amplifier (Bose)																																																										
S	2004	SSR	Body	Body Control Module																																																										
S	2004	SSR	Body	Driver Seat Module																																																										
S	2004	SSR	Body	Instrument Panel Cluster																																																										
S	2004	SSR	Body	Uplevel Radio																																																										
S	2004	SSR	Body	Remote Function Actuation																																																										
S	2004	SSR	Body	Roof and Door Module																																																										
S	2004	SSR	Body	Supplemental Inflatable Restraint																																																										
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2005	Colorado	Chassis	ABS Without Traction Control																																																										
S	2005	Colorado	Chassis	ABS With Traction Control																																																										
S	2005	Colorado	Body	Body Control Module																																																										
S	2005	Colorado	Body	Instrument Panel Cluster																																																										
S	2005	Colorado	Body	Base Radio																																																										
S	2005	Colorado	Body	Uplevel Radio																																																										
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																																										
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																										
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
S	2005	TrailBlazer	Body	Body Control Module																																																										
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2005	TrailBlazer	Body	Driver Door Module																																																										
S	2005	TrailBlazer	Body	Driver Seat Module																																																										
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2005	TrailBlazer	Body	Lift Gate Module																																																								
S	2005	TrailBlazer	Body	Passenger Door Module																																																								
S	2005	TrailBlazer	Body	Passenger Presence System																																																								
S	2005	TrailBlazer	Body	Uplevel Radio																																																								
S	2005	TrailBlazer	Body	Navigation Radio																																																								
S	2005	TrailBlazer	Body	Rear Seat Audio																																																								
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																								
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																								
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																								
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																									V															
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																								
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																								
S	2005	TrailBlazer EXT	Body	Body Control Module																																																								
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																								
S	2005	TrailBlazer EXT	Body	Driver Door Module																																																								
S	2005	TrailBlazer EXT	Body	Driver Seat Module																																																								
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																								
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																								
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																								
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																								
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																																								
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																								
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																								
S	2005	TrailBlazer EXT	Body	Navigation Radio																																																								
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																								
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																								
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																								
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																								
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																								
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																								
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																								
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																								
S	2005	Blazer	Body	Body Control Module																																																								
S	2005	Blazer	Body	Heating and Air Conditioning																																																								
S	2005	Blazer	Body	Instrument Panel Cluster																																																								
S	2005	Blazer	Body	Memory Seat Module																																																								
S	2005	Blazer	Body	Base Radio																																																								
S	2005	Blazer	Body	Uplevel Radio																																																								
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																																								
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																									V															
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
S	2005	SSR	Chassis	4WAL 3 Sensor																																																								
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																								
S	2005	SSR	Body	Amplifier (Bose)																																																								
S	2005	SSR	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2005	SSR	Body	Driver Seat Module																																																									
S	2005	SSR	Body	Instrument Panel Cluster																																																									
S	2005	SSR	Body	Uplevel Radio																																																									
S	2005	SSR	Body	Remote Function Actuation																																																									
S	2005	SSR	Body	Roof and Door Module																																																									
S	2005	SSR	Body	Supplemental Inflatable Restraint																																																									
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																									
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																									
S	2006	Colorado	Chassis	ABS Without Traction Control																																																									
S	2006	Colorado	Chassis	ABS With Traction Control																																																									
S	2006	Colorado	Body	Body Control Module																																																									
S	2006	Colorado	Body	Instrument Panel Cluster																																																									
S	2006	Colorado	Body	Passenger Presence System																																																									
S	2006	Colorado	Body	Base Radio																																																									
S	2006	Colorado	Body	Uplevel Radio																																																									
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																																									
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																																									
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								V																	
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								V																	
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																									
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																									
S	2006	TrailBlazer	Body	Body Control Module																																																									
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																									
S	2006	TrailBlazer	Body	Driver Door Module																																																									
S	2006	TrailBlazer	Body	Driver Seat Module																																																									
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																									
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																									
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																																									
S	2006	TrailBlazer	Body	Lift Gate Module																																																									
S	2006	TrailBlazer	Body	Passenger Door Module																																																									
S	2006	TrailBlazer	Body	Passenger Presence System																																																									
S	2006	TrailBlazer	Body	Uplevel Radio																																																									
S	2006	TrailBlazer	Body	Navigation Radio																																																									
S	2006	TrailBlazer	Body	Rear Seat Audio																																																									
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																									
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																									
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																									
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								V																	
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																									
S	2006	TrailBlazer EXT	Body	Body Control Module																																																									
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																									
S	2006	TrailBlazer EXT	Body	Driver Door Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2006	TrailBlazer EXT	Body	Driver Seat Module																																																								
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																								
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																								
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																								
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																								
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																																								
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																								
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																								
S	2006	TrailBlazer EXT	Body	Navigation Radio																																																								
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																								
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																								
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																								
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																								
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																								
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																								
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																							V																	
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
S	2006	SSR	Chassis	4WAL 3 Sensor																																																								
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																								
S	2006	SSR	Body	Amplifier (Bose)																																																								
S	2006	SSR	Body	Body Control Module																																																								
S	2006	SSR	Body	Driver Seat Module																																																								
S	2006	SSR	Body	Instrument Panel Cluster																																																								
S	2006	SSR	Body	Uplevel Radio																																																								
S	2006	SSR	Body	Remote Function Actuation																																																								
S	2006	SSR	Body	Roof and Door Module																																																								
S	2006	SSR	Body	Supplemental Inflatable Restraint																																																								
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																								
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																								
S	2007	Colorado	Body	Body Control Module																																																								
S	2007	Colorado	Body	Digital Radio Receiver																																																								
S	2007	Colorado	Body	Generator Battery Control Module																																																								
S	2007	Colorado	Body	Instrument Panel Cluster																																																								
S	2007	Colorado	Body	Passenger Presence System																																																								
S	2007	Colorado	Body	Base Radio																																																								
S	2007	Colorado	Body	Uplevel Radio																																																								
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																																								
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																																								
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																								
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																								
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2007	Trailblazer	Body	Body Control Module																																																											
S	2007	Trailblazer	Body	Digital Radio Receiver																																																												
S	2007	Trailblazer	Body	Disc Player and Video Display																																																												
S	2007	Trailblazer	Body	Driver Door Module																																																												
S	2007	Trailblazer	Body	Driver Seat Module																																																												
S	2007	Trailblazer	Body	Generator Battery Control Module																																																												
S	2007	Trailblazer	Body	HVAC Control Module Auto																																																												
S	2007	Trailblazer	Body	HVAC Control Module Manual																																																												
S	2007	Trailblazer	Body	Instrument Panel Cluster																																																												
S	2007	Trailblazer	Body	Lift Gate Module																																																												
S	2007	Trailblazer	Body	Passenger Door Module																																																												
S	2007	Trailblazer	Body	Passenger Presence System																																																												
S	2007	Trailblazer	Body	Uplevel Radio																																																												
S	2007	Trailblazer	Body	Navigation Radio																																																												
S	2007	Trailblazer	Body	Rear Seat Audio																																																												
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																												
S	2007	Trailblazer	Body	Theft Deterrent Module																																																												
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																												
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2008	Colorado	Body	Body Control Module																																																												
S	2008	Colorado	Body	Digital Radio Receiver																																																												
S	2008	Colorado	Body	Generator Battery Control Module																																																												
S	2008	Colorado	Body	Instrument Panel Cluster																																																												
S	2008	Colorado	Body	Passenger Presence System																																																												
S	2008	Colorado	Body	Base Radio																																																												
S	2008	Colorado	Body	Uplevel Radio																																																												
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2008	Colorado	Body	Theft Deterrent Module																																																												
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																																												
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
S	2008	TrailBlazer	Body	Body Control Module																																																												
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																												
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																												
S	2008	TrailBlazer	Body	Driver Door Module																																																												
S	2008	TrailBlazer	Body	Driver Seat Module																																																												
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																												
S	2008	TrailBlazer	Body	HVAC Control Module Auto																																																												
S	2008	TrailBlazer	Body	HVAC Control Module Manual																																																												
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2008	TrailBlazer	Body	Lift Gate Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2008	TrailBlazer	Body	Passenger Door Module																																																									
S	2008	TrailBlazer	Body	Passenger Presence System																																																										
S	2008	TrailBlazer	Body	Uplevel Radio																																																										
S	2008	TrailBlazer	Body	Navigation Radio																																																										
S	2008	TrailBlazer	Body	Rear Seat Audio																																																										
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2008	TrailBlazer	Body	Theft Deterrent Module																																																										
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																										
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
S	2009	Colorado	Chassis	Electronic Brake Control Module																																																										
S	2009	Colorado	Body	Body Control Module																																																										
S	2009	Colorado	Body	Digital Radio Receiver																																																										
S	2009	Colorado	Body	Generator Battery Control Module																																																										
S	2009	Colorado	Body	Instrument Panel Cluster																																																										
S	2009	Colorado	Body	Passenger Presence System																																																										
S	2009	Colorado	Body	Base Radio																																																										
S	2009	Colorado	Body	Uplevel Radio																																																										
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2009	Colorado	Body	Theft Deterrent Module																																																										
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																										
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																										
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																										
S	2009	TrailBlazer	Body	Body Control Module																																																										
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																										
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2009	TrailBlazer	Body	Driver Door Module																																																										
S	2009	TrailBlazer	Body	Driver Seat Module																																																										
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																										
S	2009	TrailBlazer	Body	HVAC Control Module Auto																																																										
S	2009	TrailBlazer	Body	HVAC Control Module Manual																																																										
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																																										
S	2009	TrailBlazer	Body	Lift Gate Module																																																										
S	2009	TrailBlazer	Body	Passenger Door Module																																																										
S	2009	TrailBlazer	Body	Passenger Presence System																																																										
S	2009	TrailBlazer	Body	Uplevel Radio																																																										
S	2009	TrailBlazer	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2009	TrailBlazer	Body	Rear Seat Audio																																																											
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
S	2009	TrailBlazer	Body	Theft Deterrent Module																																																											
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
S	2010	ALL	Chassis	Electronic Brake Control Module																																																											
S	2010	ALL	Body	Body Control Module																																																										
S	2010	ALL	Body	Digital Radio Receiver																																																										
S	2010	ALL	Body	Generator Battery Control Module																																																										
S	2010	ALL	Body	Instrument Panel Cluster																																																										
S	2010	ALL	Body	Passenger Presence System																																																										
S	2010	ALL	Body	Personal Audio Link Module																																																										
S	2010	ALL	Body	Base Radio																																																										
S	2010	ALL	Body	Uplevel Radio																																																										
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
S	2010	ALL	Body	Theft Deterrent Module																																																										
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																										
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2011	ALL	Chassis	Electronic Brake Control Module																																																										
S	2011	ALL	Body	Body Control Module																																																									
S	2011	ALL	Body	Digital Radio Receiver																																																									
S	2011	ALL	Body	Generator Battery Control Module																																																									
S	2011	ALL	Body	Instrument Panel Cluster																																																									
S	2011	ALL	Body	Passenger Presence System																																																									
S	2011	ALL	Body	Personal Audio Link Module																																																									
S	2011	ALL	Body	Base Radio																																																									
S	2011	ALL	Body	Uplevel Radio																																																									
S	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
S	2011	ALL	Body	Theft Deterrent Module																																																									
S	2011	ALL	Body	Vehicle Comm. Interface Module																																																									
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																											
S	2012	Colorado (First Gen)	Body	Body Control Module																																																											
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																											
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																											
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																											
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																											
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																											
S	2012	Colorado (First Gen)	Body	Base Radio																																																											
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																											
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																											
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																											
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																											
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																											
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																											
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																											
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																											
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2012	Colorado (Second Gen)	Body	Body Control Module																																																											
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																											
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																											
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																											
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																											
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																											
S	2012	S10	Powertrain	Transfer Case Control Module																																																											
S	2012	S10	Chassis	Electronic Brake Control Module																																																											
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2012	S10	Body	Body Control Module																																																										
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2012	S10	Body	Instrument Cluster																																																											
S	2012	S10	Body	Trailer Interface Control Module																																																											
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																									
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																									
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																									
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																									
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																									
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																									
S	2013	Colorado	Powertrain	Transfer Case Control Module																																																									
S	2013	Colorado	Chassis	Electronic Brake Control Module																																																									
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2013	Colorado	Body	Body Control Module																																																									
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2013	Colorado	Body	Instrument Cluster																																																									
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																									
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																									
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																									
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																									
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																									
S	2013	S10	Powertrain	Transfer Case Control Module																																																									
S	2013	S10	Chassis	Electronic Brake Control Module																																																									
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2013	S10	Body	Body Control Module																																																									
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2013	S10	Body	Instrument Cluster																																																									
S	2013	S10	Body	Trailer Interface Control Module																																																									
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																									
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																									
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																									
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																									
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																									
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																									
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																									
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																									
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2013	Trailblazer	Body	Body Control Module																																																									
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2013	Trailblazer	Body	Instrument Cluster																																																									
S	2013	Trailblazer	Body	Trailer Interface Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2013	Trailblazer	Body	Parking Assist Control Module																																																									
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																									
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																									
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																									
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2014	Colorado	Body	Body Control Module																																																									
S	2014	Colorado	Body	Body Control Module																																																									
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	Colorado	Body	Instrument Cluster																																																									
S	2014	Colorado	Body	Radio																																																									
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																									
S	2014	Colorado	Body	Parking Assist Control Module																																																									
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2014	S10	Powertrain	Transfer Case Control Module																																																									
S	2014	S10	Chassis	Electronic Brake Control Module																																																									
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2014	S10	Body	Body Control Module																																																									
S	2014	S10	Body	Body Control Module																																																									
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	S10	Body	Instrument Cluster																																																									
S	2014	S10	Body	Trailer Interface Control Module																																																									
S	2014	S10	Body	Radio																																																									
S	2014	S10	Body	Parking Assist Control Module																																																									
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																									
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																										
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2014	Trailblazer	Body	Body Control Module																																																										
S	2014	Trailblazer	Body	Body Control Module																																																										
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2014	Trailblazer	Body	Instrument Cluster																																																										
S	2014	Trailblazer	Body	Trailer Interface Control Module																																																										
S	2014	Trailblazer	Body	Parking Assist Control Module																																																										
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2015	Colorado	Powertrain	Chassis Control Module																																																										
S	2015	Colorado	Powertrain	Transfer Case Control Module																																																										
S	2015	Colorado	Chassis	Electronic Brake Control Module																																																										
S	2015	Colorado	Chassis	Power Steering Control Module																																																										
S	2015	Colorado	Body	Body Control Module																																																										
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Colorado	Body	Passenger Presence Module																																																										
S	2015	Colorado	Body	Radio																																																										
S	2015	Colorado	Body	Amplifier																																																										
S	2015	Colorado	Body	Human Machine Interface Control Module																																																										
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																																										
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																										
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																										
S	2015	Colorado	Body	Frontview Camera Module																																																										
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																										
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																										
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	Colorado (MMM)	Body	Body Control Module																																																										
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2015	Colorado (MMM)	Body	Instrument Cluster																																																										
S	2015	Colorado (MMM)	Body	Radio																																																										
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																										
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	S10	Powertrain	Transfer Case Control Module																																																										
S	2015	S10	Chassis	Electronic Brake Control Module																																																										
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	S10	Body	Body Control Module																																																										
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	S10	Body	Instrument Cluster																																																										
S	2015	S10	Body	Trailer Interface Control Module																																																										
S	2015	S10	Body	Radio																																																										
S	2015	S10	Body	Telematics Communication Interface Control Module																																																										
S	2015	S10	Body	Parking Assist Control Module																																																										
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																										
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																										
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	Trailblazer	Body	Body Control Module																																																										
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Trailblazer	Body	Instrument Cluster																																																										
S	2015	Trailblazer	Body	Trailer Interface Control Module																																																										
S	2015	Trailblazer	Body	Radio																																																										
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																										
S	2015	Trailblazer	Body	Parking Assist Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																											
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																											
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																											
S	2016	Colorado (1GC)	Body	Body Control Module																																																											
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																																											
S	2016	Colorado (1GC)	Body	Radio Controls																																																											
S	2016	Colorado (1GC)	Body	HVAC Controls																																																											
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																											
S	2016	Colorado (1GC)	Body	Radio																																																											
S	2016	Colorado (1GC)	Body	Amplifier																																																											
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																											
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																											
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																											
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																											
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																											
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																																											
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																											
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																											
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																											
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																											
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2016	Colorado (MMM)	Body	Body Control Module																																																											
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2016	Colorado (MMM)	Body	Instrument Cluster																																																											
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																											
S	2016	Colorado (MMM)	Body	Radio																																																											
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																											
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																											
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																											
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																											
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																											
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																											
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																											
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
S	2016	S10	Powertrain	Transfer Case Control Module																																																											
S	2016	S10	Chassis	Electronic Brake Control Module																																																											
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2016	S10	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2016	S10	Body	Instrument Cluster																																																												
S	2016	S10	Body	Trailer Interface Control Module																																																												
S	2016	S10	Body	Radio																																																												
S	2016	S10	Body	Telematics Communication Interface Control Module																																																												
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																												
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																												
S	2016	S10	Body	Parking Assist Control Module																																																												
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																												
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																												
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2016	Trailblazer	Body	Body Control Module																																																												
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2016	Trailblazer	Body	Instrument Cluster																																																												
S	2016	Trailblazer	Body	Trailer Interface Control Module																																																												
S	2016	Trailblazer	Body	Radio																																																											
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																												
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																												
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																												
S	2016	Trailblazer	Body	Parking Assist Control Module																																																												
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2004	S10	Chassis	4WAL 3 Sensor																																																												
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																												
T	2004	S10	Body	Body Control Module																																																												
T	2004	S10	Body	Instrument Panel Cluster																																																												
T	2004	S10	Body	Base Radio																																																												
T	2004	S10	Body	Uplevel Radio																																																												
T	2004	S10	Body	Supplemental Inflatable Restraint																																																												
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2004	Colorado	Chassis	ABS Without Traction Control																																																												
T	2004	Colorado	Chassis	ABS With Traction Control																																																												
T	2004	Colorado	Body	Body Control Module																																																												
T	2004	Colorado	Body	Instrument Panel Cluster																																																												
T	2004	Colorado	Body	OnStar																																																											
T	2004	Colorado	Body	Base Radio																																																											
T	2004	Colorado	Body	Uplevel Radio																																																											
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																																											
T	2004	Colorado	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																									
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																									
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																									
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																									
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																									
T	2004	TrailBlazer	Body	Body Control Module																																																									
T	2004	TrailBlazer	Body	Driver Door Module																																																									
T	2004	TrailBlazer	Body	Driver Seat Module																																																									
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																									
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																									
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																																									
T	2004	TrailBlazer	Body	Lift Gate Module																																																									
T	2004	TrailBlazer	Body	OnStar																																																									
T	2004	TrailBlazer	Body	Passenger Door Module																																																									
T	2004	TrailBlazer	Body	Uplevel Radio																																																									
T	2004	TrailBlazer	Body	Navigation Radio																																																									
T	2004	TrailBlazer	Body	Rear Seat Audio																																																									
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																									
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																									
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																									
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																									
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																									
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																									
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																									
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																									
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																									
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																									
T	2004	TrailBlazer EXT	Body	Body Control Module																																																									
T	2004	TrailBlazer EXT	Body	Driver Door Module																																																									
T	2004	TrailBlazer EXT	Body	Driver Seat Module																																																									
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																									
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																									
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																									
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																									
T	2004	TrailBlazer EXT	Body	OnStar																																																									
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																																									
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																									
T	2004	TrailBlazer EXT	Body	Navigation Radio																																																									
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																									
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																									
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																									
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																									
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																									
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																									
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Blazer	Body	Body Control Module																																																									
T	2004	Blazer	Body	Heating and Air Conditioning																																																									
T	2004	Blazer	Body	Instrument Panel Cluster																																																									
T	2004	Blazer	Body	Memory Seat Module																																																									
T	2004	Blazer	Body	Base Radio																																																									
T	2004	Blazer	Body	Uplevel Radio																																																									
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																																									
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																									
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																									
T	2005	Colorado	Chassis	ABS Without Traction Control																																																									
T	2005	Colorado	Chassis	ABS With Traction Control																																																									
T	2005	Colorado	Body	Body Control Module																																																									
T	2005	Colorado	Body	Instrument Panel Cluster																																																									
T	2005	Colorado	Body	Base Radio																																																									
T	2005	Colorado	Body	Uplevel Radio																																																									
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																																									
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																																									
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																									
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																									
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																									
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																									
T	2005	TrailBlazer	Body	Body Control Module																																																									
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																									
T	2005	TrailBlazer	Body	Driver Door Module																																																									
T	2005	TrailBlazer	Body	Driver Seat Module																																																									
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																									
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																									
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																																									
T	2005	TrailBlazer	Body	Lift Gate Module																																																									
T	2005	TrailBlazer	Body	Passenger Door Module																																																									
T	2005	TrailBlazer	Body	Passenger Presence System																																																									
T	2005	TrailBlazer	Body	Uplevel Radio																																																									
T	2005	TrailBlazer	Body	Navigation Radio																																																									
T	2005	TrailBlazer	Body	Rear Seat Audio																																																									
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																									
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																									
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																									
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																									
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																									V																
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																								
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																								
T	2005	TrailBlazer EXT	Body	Body Control Module																																																								
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																								
T	2005	TrailBlazer EXT	Body	Driver Door Module																																																								
T	2005	TrailBlazer EXT	Body	Driver Seat Module																																																								
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																								
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																								
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																								
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																								
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																																								
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																								
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																								
T	2005	TrailBlazer EXT	Body	Navigation Radio																																																								
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																								
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																								
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																								
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																								
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																								
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																								
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																								
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																								
T	2005	Blazer	Body	Body Control Module																																																								
T	2005	Blazer	Body	Heating and Air Conditioning																																																								
T	2005	Blazer	Body	Instrument Panel Cluster																																																								
T	2005	Blazer	Body	Memory Seat Module																																																								
T	2005	Blazer	Body	Base Radio																																																								
T	2005	Blazer	Body	Uplevel Radio																																																								
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																																								
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																								
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																								
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																								
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																								
T	2006	Colorado	Chassis	ABS Without Traction Control																																																								
T	2006	Colorado	Chassis	ABS With Traction Control																																																								
T	2006	Colorado	Body	Body Control Module																																																								
T	2006	Colorado	Body	Instrument Panel Cluster																																																								
T	2006	Colorado	Body	Passenger Presence System																																																								
T	2006	Colorado	Body	Base Radio																																																								
T	2006	Colorado	Body	Uplevel Radio																																																								
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																																								
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																																								
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																									V															
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																									V															
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																								
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																								
T	2006	TrailBlazer	Body	Body Control Module																																																								
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																								
T	2006	TrailBlazer	Body	Driver Door Module																																																								
T	2006	TrailBlazer	Body	Driver Seat Module																																																								
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																								
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																								
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																																								
T	2006	TrailBlazer	Body	Lift Gate Module																																																								
T	2006	TrailBlazer	Body	Passenger Door Module																																																								
T	2006	TrailBlazer	Body	Passenger Presence System																																																								
T	2006	TrailBlazer	Body	Uplevel Radio																																																								
T	2006	TrailBlazer	Body	Navigation Radio																																																								
T	2006	TrailBlazer	Body	Rear Seat Audio																																																								
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																								
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																								
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																										V														
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																								
T	2006	TrailBlazer EXT	Body	Body Control Module																																																								
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																								
T	2006	TrailBlazer EXT	Body	Driver Door Module																																																								
T	2006	TrailBlazer EXT	Body	Driver Seat Module																																																								
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																								
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																								
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																								
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																								
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																																								
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																								
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																								
T	2006	TrailBlazer EXT	Body	Navigation Radio																																																								
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																								
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																								
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																								
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																								
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																								
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																												
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																												
T	2007	Colorado	Body	Body Control Module																																																												
T	2007	Colorado	Body	Digital Radio Receiver																																																												
T	2007	Colorado	Body	Generator Battery Control Module																																																												
T	2007	Colorado	Body	Instrument Panel Cluster																																																												
T	2007	Colorado	Body	Passenger Presence System																																																												
T	2007	Colorado	Body	Base Radio																																																												
T	2007	Colorado	Body	Uplevel Radio																																																												
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																																												
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																																												
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																												
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																												
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																												
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																												
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																												
T	2007	Trailblazer	Body	Body Control Module																																																												
T	2007	Trailblazer	Body	Digital Radio Receiver																																																												
T	2007	Trailblazer	Body	Disc Player and Video Display																																																												
T	2007	Trailblazer	Body	Driver Door Module																																																												
T	2007	Trailblazer	Body	Driver Seat Module																																																												
T	2007	Trailblazer	Body	Generator Battery Control Module																																																												
T	2007	Trailblazer	Body	HVAC Control Module Auto																																																												
T	2007	Trailblazer	Body	HVAC Control Module Manual																																																												
T	2007	Trailblazer	Body	Instrument Panel Cluster																																																												
T	2007	Trailblazer	Body	Lift Gate Module																																																												
T	2007	Trailblazer	Body	Passenger Door Module																																																												
T	2007	Trailblazer	Body	Passenger Presence System																																																												
T	2007	Trailblazer	Body	Uplevel Radio																																																												
T	2007	Trailblazer	Body	Navigation Radio																																																												
T	2007	Trailblazer	Body	Rear Seat Audio																																																												
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																												
T	2007	Trailblazer	Body	Theft Deterrent Module																																																												
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																												
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																												
T	2008	Colorado	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2008	Colorado	Body	Digital Radio Receiver																																																											
T	2008	Colorado	Body	Generator Battery Control Module																																																												
T	2008	Colorado	Body	Instrument Panel Cluster																																																												
T	2008	Colorado	Body	Passenger Presence System																																																												
T	2008	Colorado	Body	Base Radio																																																												
T	2008	Colorado	Body	Uplevel Radio																																																												
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																																												
T	2008	Colorado	Body	Theft Deterrent Module																																																												
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																																												
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
T	2008	TrailBlazer	Body	Body Control Module																																																												
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																												
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																												
T	2008	TrailBlazer	Body	Driver Door Module																																																												
T	2008	TrailBlazer	Body	Driver Seat Module																																																												
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																												
T	2008	TrailBlazer	Body	HVAC Control Module Auto																																																												
T	2008	TrailBlazer	Body	HVAC Control Module Manual																																																												
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																																												
T	2008	TrailBlazer	Body	Lift Gate Module																																																												
T	2008	TrailBlazer	Body	Passenger Door Module																																																												
T	2008	TrailBlazer	Body	Passenger Presence System																																																												
T	2008	TrailBlazer	Body	Uplevel Radio																																																												
T	2008	TrailBlazer	Body	Navigation Radio																																																												
T	2008	TrailBlazer	Body	Rear Seat Audio																																																												
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
T	2008	TrailBlazer	Body	Theft Deterrent Module																																																												
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																												
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																												
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																												
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																												
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																												
T	2009	Colorado	Chassis	Electronic Brake Control Module																																																												
T	2009	Colorado	Body	Body Control Module																																																												
T	2009	Colorado	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2009	Colorado	Body	Generator Battery Control Module																																																											
T	2009	Colorado	Body	Instrument Panel Cluster																																																												
T	2009	Colorado	Body	Passenger Presence System																																																												
T	2009	Colorado	Body	Base Radio																																																												
T	2009	Colorado	Body	Uplevel Radio																																																												
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																																												
T	2009	Colorado	Body	Theft Deterrent Module																																																												
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
T	2009	TrailBlazer	Body	Body Control Module																																																												
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																												
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																												
T	2009	TrailBlazer	Body	Driver Door Module																																																												
T	2009	TrailBlazer	Body	Driver Seat Module																																																												
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																												
T	2009	TrailBlazer	Body	HVAC Control Module Auto																																																												
T	2009	TrailBlazer	Body	HVAC Control Module Manual																																																												
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																																												
T	2009	TrailBlazer	Body	Lift Gate Module																																																												
T	2009	TrailBlazer	Body	Passenger Door Module																																																												
T	2009	TrailBlazer	Body	Passenger Presence System																																																												
T	2009	TrailBlazer	Body	Uplevel Radio																																																												
T	2009	TrailBlazer	Body	Navigation Radio																																																												
T	2009	TrailBlazer	Body	Rear Seat Audio																																																												
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
T	2009	TrailBlazer	Body	Theft Deterrent Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																												
T	2010	ALL	Chassis	Electronic Brake Control Module																																																												
T	2010	ALL	Body	Body Control Module																																																												
T	2010	ALL	Body	Digital Radio Receiver																																																												
T	2010	ALL	Body	Generator Battery Control Module																																																												
T	2010	ALL	Body	Instrument Panel Cluster																																																												
T	2010	ALL	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2010	ALL	Body	Personal Audio Link Module																																																										
T	2010	ALL	Body	Base Radio																																																										
T	2010	ALL	Body	Uplevel Radio																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Theft Deterrent Module																																																										
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																										
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
T	2011	ALL	Chassis	Electronic Brake Control Module																																																										
T	2011	ALL	Body	Body Control Module																																																										
T	2011	ALL	Body	Digital Radio Receiver																																																										
T	2011	ALL	Body	Generator Battery Control Module																																																										
T	2011	ALL	Body	Instrument Panel Cluster																																																										
T	2011	ALL	Body	Passenger Presence System																																																										
T	2011	ALL	Body	Personal Audio Link Module																																																										
T	2011	ALL	Body	Base Radio																																																										
T	2011	ALL	Body	Uplevel Radio																																																										
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2011	ALL	Body	Theft Deterrent Module																																																										
T	2011	ALL	Body	Vehicle Comm. Interface Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																										
T	2012	Colorado (First Gen)	Body	Body Control Module																																																										
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																										
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																										
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																										
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																										
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																										
T	2012	Colorado (First Gen)	Body	Base Radio																																																										
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																									
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																										
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2012	Colorado (Second Gen)	Body	Body Control Module																																																										
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																										
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																										
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2012	S10	Powertrain	Transfer Case Control Module																																																										
T	2012	S10	Chassis	Electronic Brake Control Module																																																										
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2012	S10	Body	Body Control Module																																																										
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2012	S10	Body	Instrument Cluster																																																										
T	2012	S10	Body	Trailer Interface Control Module																																																										
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2013	Colorado	Powertrain	Transfer Case Control Module																																																										
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2013	Colorado	Body	Body Control Module																																																									
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2013	Colorado	Body	Instrument Cluster																																																									
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																									
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																									
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																									
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																									
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																									
T	2013	S10	Powertrain	Transfer Case Control Module																																																									
T	2013	S10	Chassis	Electronic Brake Control Module																																																									
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2013	S10	Body	Body Control Module																																																									
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2013	S10	Body	Instrument Cluster																																																									
T	2013	S10	Body	Trailer Interface Control Module																																																									
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																									
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																									
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																									
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																									
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																									
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																									
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																									
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																									
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2013	Trailblazer	Body	Body Control Module																																																									
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2013	Trailblazer	Body	Instrument Cluster																																																									
T	2013	Trailblazer	Body	Trailer Interface Control Module																																																									
T	2013	Trailblazer	Body	Parking Assist Control Module																																																									
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																									
T	2014	Colorado	Powertrain	Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																										
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	Colorado	Body	Body Control Module																																																										
T	2014	Colorado	Body	Body Control Module																																																										
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Colorado	Body	Instrument Cluster																																																										
T	2014	Colorado	Body	Radio																																																										
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																										
T	2014	Colorado	Body	Parking Assist Control Module																																																										
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2014	S10	Powertrain	Transfer Case Control Module																																																										
T	2014	S10	Chassis	Electronic Brake Control Module																																																										
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	S10	Body	Body Control Module																																																										
T	2014	S10	Body	Body Control Module																																																										
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	S10	Body	Instrument Cluster																																																										
T	2014	S10	Body	Trailer Interface Control Module																																																										
T	2014	S10	Body	Radio																																																										
T	2014	S10	Body	Parking Assist Control Module																																																										
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																										
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																										
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																										
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																										
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																										
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																										
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
T	2014	Trailblazer	Body	Body Control Module																																																										
T	2014	Trailblazer	Body	Body Control Module																																																										
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
T	2014	Trailblazer	Body	Instrument Cluster																																																										
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																										
T	2014	Trailblazer	Body	Parking Assist Control Module																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2015	Colorado	Powertrain	Chassis Control Module																																																									
T	2015	Colorado	Powertrain	Transfer Case Control Module																																																									
T	2015	Colorado	Chassis	Electronic Brake Control Module																																																									
T	2015	Colorado	Chassis	Power Steering Control Module																																																									
T	2015	Colorado	Body	Body Control Module																																																									
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Colorado	Body	Passenger Presence Module																																																									
T	2015	Colorado	Body	Radio																																																									
T	2015	Colorado	Body	Amplifier																																																									
T	2015	Colorado	Body	Human Machine Interface Control Module																																																									
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																																									
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																									
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																									
T	2015	Colorado	Body	Frontview Camera Module																																																									
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																									
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																									
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2015	Colorado (MMM)	Body	Body Control Module																																																									
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Colorado (MMM)	Body	Instrument Cluster																																																									
T	2015	Colorado (MMM)	Body	Radio																																																									
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																									
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																									
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																												
T	2015	S10	Powertrain	Transfer Case Control Module																																																												
T	2015	S10	Chassis	Electronic Brake Control Module																																																												
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2015	S10	Body	Body Control Module																																																												
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2015	S10	Body	Instrument Cluster																																																												
T	2015	S10	Body	Trailer Interface Control Module																																																												
T	2015	S10	Body	Radio																																																												
T	2015	S10	Body	Telematics Communication Interface Control Module																																																												
T	2015	S10	Body	Parking Assist Control Module																																																												
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																												
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																												
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																												
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2015	Trailblazer	Body	Body Control Module																																																												
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2015	Trailblazer	Body	Instrument Cluster																																																												
T	2015	Trailblazer	Body	Trailer Interface Control Module																																																												
T	2015	Trailblazer	Body	Radio																																																												
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																												
T	2015	Trailblazer	Body	Parking Assist Control Module																																																												
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																												
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																												
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																												
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																												
T	2016	Colorado (1GC)	Body	Body Control Module																																																												
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																																												
T	2016	Colorado (1GC)	Body	Radio Controls																																																												
T	2016	Colorado (1GC)	Body	HVAC Controls																																																												
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																												
T	2016	Colorado (1GC)	Body	Radio																																																												
T	2016	Colorado (1GC)	Body	Amplifier																																																												
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																											
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																											
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																											
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																											
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																											
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																											
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																											
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																											
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2016	Colorado (MMM)	Body	Body Control Module																																																											
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																											
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																											
T	2016	Colorado (MMM)	Body	Radio																																																											
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																											
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																											
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																											
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																											
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																											
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																											
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
T	2016	S10	Powertrain	Transfer Case Control Module																																																											
T	2016	S10	Chassis	Electronic Brake Control Module																																																											
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2016	S10	Body	Body Control Module																																																											
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2016	S10	Body	Instrument Cluster																																																											
T	2016	S10	Body	Trailer Interface Control Module																																																											
T	2016	S10	Body	Radio																																																											
T	2016	S10	Body	Telematics Communication Interface Control Module																																																											
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																											
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																											
T	2016	S10	Body	Parking Assist Control Module																																																											
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																												
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																												
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2016	Trailblazer	Body	Body Control Module																																																												
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	Trailblazer	Body	Instrument Cluster																																																												
T	2016	Trailblazer	Body	Trailer Interface Control Module																																																												
T	2016	Trailblazer	Body	Radio																																																												
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																												
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																												
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	Trailblazer	Body	Parking Assist Control Module																																																												
V	2009	ALL	Powertrain	Engine Control Module																																																												
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2009	ALL	Powertrain	Rear Drive System																																																												
V	2009	ALL	Powertrain	Transmission Control Module																																																												
V	2009	ALL	Chassis	Electronic Brake Control Module																																																												
V	2009	ALL	Body	Body Control Module																																																												
V	2009	ALL	Body	Digital Radio Receiver																																																												
V	2009	ALL	Body	Driver Door Switch																																																												
V	2009	ALL	Body	Heated Seat Module																																																												
V	2009	ALL	Body	HVAC Control Module Auto																																																												
V	2009	ALL	Body	HVAC Control Module Manual																																																												
V	2009	ALL	Body	Instrument Panel Cluster																																																												
V	2009	ALL	Body	Lift Gate Module																																																												
V	2009	ALL	Body	Park Assist Module																																																												
V	2009	ALL	Body	Passenger Door Switch																																																												
V	2009	ALL	Body	Passenger Presence System																																																												
V	2009	ALL	Body	Radio																																																												
V	2009	ALL	Body	Rear HVAC/RSA																																																												
V	2009	ALL	Body	Rollover Sensor																																																												
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2009	ALL	Body	Theft Deterrent Module																																																												
V	2010	ALL	Powertrain	Engine Control Module																																																												
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2010	ALL	Powertrain	Rear Drive System																																																												
V	2010	ALL	Powertrain	Transmission Control Module																																																												
V	2010	ALL	Chassis	Electronic Brake Control Module																																																												
V	2010	ALL	Body	Body Control Module																																																												
V	2010	ALL	Body	Digital Radio Receiver																																																												
V	2010	ALL	Body	Driver Door Switch																																																												
V	2010	ALL	Body	Heated Seat Module																																																												
V	2010	ALL	Body	HVAC Control Module Auto																																																												
V	2010	ALL	Body	HVAC Control Module Manual																																																												
V	2010	ALL	Body	Instrument Panel Cluster																																																												
V	2010	ALL	Body	Lift Gate Module																																																												
V	2010	ALL	Body	Park Assist Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
V	2010	ALL	Body	Passenger Door Switch																																																											
V	2010	ALL	Body	Passenger Presence System																																																											
V	2010	ALL	Body	Radio																																																											
V	2010	ALL	Body	Rear HVAC/RSA																																																											
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2010	ALL	Body	Theft Deterrent Module																																																											
V	2011	ALL	Powertrain	Engine Control Module																																																											
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2011	ALL	Powertrain	Rear Drive System																																																											
V	2011	ALL	Powertrain	Transmission Control Module																																																											
V	2011	ALL	Chassis	Electronic Brake Control Module																																																											
V	2011	ALL	Body	Body Control Module																																																											
V	2011	ALL	Body	Digital Radio Receiver																																																											
V	2011	ALL	Body	Driver Door Switch																																																											
V	2011	ALL	Body	Heated Seat Module																																																											
V	2011	ALL	Body	HVAC Control Module Auto																																																											
V	2011	ALL	Body	HVAC Control Module Manual																																																											
V	2011	ALL	Body	Instrument Panel Cluster																																																											
V	2011	ALL	Body	Lift Gate Module																																																											
V	2011	ALL	Body	Park Assist Module																																																											
V	2011	ALL	Body	Passenger Door Switch																																																											
V	2011	ALL	Body	Passenger Presence System																																																											
V	2011	ALL	Body	Radio																																																											
V	2011	ALL	Body	Rear HVAC/RSA																																																											
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2011	ALL	Body	Theft Deterrent Module																																																											
V	2012	ALL	Powertrain	Engine Control Module																																																											
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2012	ALL	Powertrain	Rear Drive System																																																											
V	2012	ALL	Powertrain	Transmission Control Module																																																											
V	2012	ALL	Chassis	Electronic Brake Control Module																																																											
V	2012	ALL	Body	Body Control Module																																																											
V	2012	ALL	Body	Digital Radio Receiver																																																											
V	2012	ALL	Body	Driver Door Switch																																																											
V	2012	ALL	Body	Heated Seat Module																																																											
V	2012	ALL	Body	HVAC Control Module Auto																																																											
V	2012	ALL	Body	HVAC Control Module Manual																																																											
V	2012	ALL	Body	Instrument Panel Cluster																																																											
V	2012	ALL	Body	Lift Gate Module																																																											
V	2012	ALL	Body	Park Assist Module																																																											
V	2012	ALL	Body	Passenger Door Switch																																																											
V	2012	ALL	Body	Passenger Presence System																																																											
V	2012	ALL	Body	Radio																																																											
V	2012	ALL	Body	Rear HVAC/RSA																																																											
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2012	ALL	Body	Theft Deterrent Module																																																											
V	2013	ALL	Powertrain	Engine Control Module																																																											
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2013	ALL	Powertrain	Rear Drive System																																																											
V	2013	ALL	Powertrain	Transmission Control Module																																																											
V	2013	ALL	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
V	2013	ALL	Body	Body Control Module																																																									
V	2013	ALL	Body	Digital Radio Receiver																																																									
V	2013	ALL	Body	Driver Door Switch																																																									
V	2013	ALL	Body	Heated Seat Module																																																									
V	2013	ALL	Body	HVAC Control Module Auto																																																									
V	2013	ALL	Body	HVAC Control Module Manual																																																									
V	2013	ALL	Body	Instrument Panel Cluster																																																									
V	2013	ALL	Body	Left Side Object Detection Module																																																									
V	2013	ALL	Body	Lift Gate Module																																																									
V	2013	ALL	Body	Park Assist Module																																																									
V	2013	ALL	Body	Passenger Door Switch																																																									
V	2013	ALL	Body	Passenger Presence System																																																									
V	2013	ALL	Body	Radio																																																									
V	2013	ALL	Body	Rear HVAC/RSA																																																									
V	2013	ALL	Body	Right Side Object Detection Module																																																									
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2013	ALL	Body	Theft Deterrent Module																																																									
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2014	Traverse	Powertrain	Chassis Control Module																																																									
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																									
V	2014	Traverse	Chassis	Electronic Brake Control Module																																																									
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																									
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2014	Traverse	Body	Passenger Presence Module																																																									
V	2014	Traverse	Body	Instrument Cluster																																																									
V	2014	Traverse	Body	Radio																																																									
V	2014	Traverse	Body	Rear Audio Control Module																																																									
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																									
V	2014	Traverse	Body	Personal Audio Link Control Module																																																									
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																											V														
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																											V														
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																									
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																									
V	2014	Traverse	Body	Liftgate Control Module																																																									
V	2014	Traverse	Body	Seat Memory Control Module																																																									
V	2014	Traverse	Body	Front Seat Heating Control Module																																																									
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																									
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																									
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																									
V	2014	Traverse	Body	Parking Assist Control Module																																																									
V	2014	Traverse	Body	Frontview Camera Module																																																									
V	2014	Traverse	Body	Theft Deterrent Module																																																									
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																									
V	2015	Traverse	Chassis	Electronic Brake Control Module																																																									
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Traverse	Body	Passenger Presence Module																																																										
V	2015	Traverse	Body	Instrument Cluster																																																										
V	2015	Traverse	Body	Radio																																																										
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																										V																
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																										V																
V	2015	Traverse	Body	Liftgate Control Module																																																										
V	2015	Traverse	Body	Seat Memory Control Module																																																										
V	2015	Traverse	Body	Front Seat Heating Control Module																																																										
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2015	Traverse	Body	Parking Assist Control Module																																																										
V	2015	Traverse	Body	Frontview Camera Module																																																										
V	2015	Traverse	Body	Theft Deterrent Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Traverse	Chassis	Electronic Brake Control Module																																																										
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Traverse	Body	Passenger Presence Module																																																										
V	2016	Traverse	Body	Instrument Cluster																																																										
V	2016	Traverse	Body	Radio																																																										
V	2016	Traverse	Body	Rear Audio Control Module																																																										
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2016	Traverse	Body	Personal Audio Link Control Module																																																										
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																										
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																										V																
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																										V																
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Liftgate Control Module																																																										
V	2016	Traverse	Body	Seat Memory Control Module																																																										
V	2016	Traverse	Body	Front Seat Heating Control Module																																																										
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2016	Traverse	Body	Parking Assist Control Module																																																										
V	2016	Traverse	Body	Frontview Camera Module																																																										
V	2016	Traverse	Body	Theft Deterrent Module																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																												
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																												
A	2011	Orlando	Chassis	Parking Brake Control Module																																																												
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2011	Orlando	Chassis	Power Steering Control Module																																																												
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2011	Orlando	Body	Body Control Module																																																												
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2011	Orlando	Body	Instrument Cluster																																																												
A	2011	Orlando	Body	Trailer Interface Control Module																																																												
A	2011	Orlando	Body	Radio																																																												
A	2011	Orlando	Body	Multimedia Player Interface Module																																																												
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																												
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																												
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																												
A	2011	Orlando	Body	Keyless Entry Control Module																																																												
A	2011	Orlando	Body	Parking Assist Control Module																																																												
A	2011	Orlando	Body	Steering Column Lock Control Module																																																												
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																												
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																												
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																												
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																												
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																												
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																												
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																												
A	2012	Orlando	Chassis	Parking Brake Control Module																																																												
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2012	Orlando	Chassis	Power Steering Control Module																																																												
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2012	Orlando	Body	Body Control Module																																																												
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2012	Orlando	Body	Instrument Cluster																																																												
A	2012	Orlando	Body	Trailer Interface Control Module																																																												
A	2012	Orlando	Body	Radio																																																											
A	2012	Orlando	Body	Multimedia Player Interface Module																																																											
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
A	2012	Orlando	Body	Keyless Entry Control Module																																																											
A	2012	Orlando	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2012	Orlando	Body	Steering Column Lock Control Module																																																											
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																											
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																											
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																											
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																											
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																											
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																											
A	2013	Orlando	Chassis	Parking Brake Control Module																																																											
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2013	Orlando	Chassis	Power Steering Control Module																																																											
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2013	Orlando	Body	Body Control Module																																																										
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2013	Orlando	Body	Instrument Cluster																																																											
A	2013	Orlando	Body	Radio																																																										
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																											
A	2013	Orlando	Body	Multimedia Player Interface Module																																																											
A	2013	Orlando	Body	Mobile Telephone Control Module																																																											
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																											
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																											
A	2013	Orlando	Body	Front Seat Heating Control Module																																																											
A	2013	Orlando	Body	Keyless Entry Control Module																																																											
A	2013	Orlando	Body	Parking Assist Control Module																																																											
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2014	Orlando	Chassis	Power Steering Control Module																																																										
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2014	Orlando	Body	Body Control Module																																																										
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2014	Orlando	Body	Instrument Cluster																																																										
A	2014	Orlando	Body	Radio																																																										
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2014	Orlando	Body	Multimedia Player Interface Module																																																										
A	2014	Orlando	Body	Mobile Telephone Control Module																																																										
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2014	Orlando	Body	Front Seat Heating Control Module																																																										
A	2014	Orlando	Body	Rear Seat Heating Control Module																																																										
A	2014	Orlando	Body	Keyless Entry Control Module																																																										
A	2014	Orlando	Body	Parking Assist Control Module																																																										
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2015	Orlando	Chassis	Power Steering Control Module																																																										
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2015	Orlando	Body	Body Control Module																																																										
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2015	Orlando	Body	Instrument Cluster																																																										
A	2015	Orlando	Body	Radio																																																										
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2015	Orlando	Body	Mobile Telephone Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																										
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2015	Orlando	Body	Front Seat Heating Control Module																																																										
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																										
A	2015	Orlando	Body	Keyless Entry Control Module																																																										
A	2015	Orlando	Body	Parking Assist Control Module																																																										
A	2015	Orlando	Body	Frontview Camera Module																																																										
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																										
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																										
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																										
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2016	Orlando	Chassis	Power Steering Control Module																																																										
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2016	Orlando	Body	Body Control Module																																																										
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2016	Orlando	Body	Instrument Cluster																																																										
A	2016	Orlando	Body	Radio																																																										
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2016	Orlando	Body	Multimedia Player Interface Module																																																										
A	2016	Orlando	Body	Mobile Telephone Control Module																																																										
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																										
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2016	Orlando	Body	Front Seat Heating Control Module																																																										
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																										
A	2016	Orlando	Body	Keyless Entry Control Module																																																										
A	2016	Orlando	Body	Parking Assist Control Module																																																										
A	2016	Orlando	Body	Frontview Camera Module																																																										
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																																																										
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2009	N200	Chassis	Electronic Brake Control Module																																																										
C	2009	N200	Body	Supplemental Inflatable Restraint																																																										
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2009	N300	Chassis	Electronic Brake Control Module																																																										
C	2009	N300	Body	Supplemental Inflatable Restraint																																																										
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2010	N200	Chassis	Electronic Brake Control Module																																																										
C	2010	N200	Body	Supplemental Inflatable Restraint																																																										
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2010	N300	Chassis	Electronic Brake Control Module																																																										
C	2010	N300	Body	Supplemental Inflatable Restraint																																																										
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2011	N200	Chassis	Electronic Brake Control Module																																																										
C	2011	N200	Body	Supplemental Inflatable Restraint																																																										
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2011	N300	Chassis	Electronic Brake Control Module																																																										
C	2011	N300	Body	Supplemental Inflatable Restraint																																																										
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2012	N200	Chassis	Electronic Brake Control Module																																																										
C	2012	N200	Body	Supplemental Inflatable Restraint																																																										
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																										
C	2012	N300	Chassis	Electronic Brake Control Module																																																										
C	2012	N300	Body	Supplemental Inflatable Restraint																																																										
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2013	N300	Chassis	Electronic Brake Control Module																																																										
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																																										
C	2014	N300	Chassis	Electronic Brake Control Module																																																										
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																																										
C	2015	Max	Chassis	Electronic Brake Control Module																																																										
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																																										
C	2015	Move	Chassis	Electronic Brake Control Module																																																										
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																																										
C	2015	N300	Chassis	Electronic Brake Control Module																																																										
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																																										
C	2016	Max	Chassis	Electronic Brake Control Module																																																										
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																																										
C	2016	Move	Chassis	Electronic Brake Control Module																																																										
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module																																																										
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																																										
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																																										
C	2016	N300	Chassis	Electronic Brake Control Module																																																										
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																										
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																										
M	2015	City Express	Chassis	Electronic Brake Control Module																																																										
M	2015	City Express	Chassis	Power Steering Control Module																																																										
M	2015	City Express	Body	Body Control Module																																																									
M	2015	City Express	Body	Underhood Fuse Block																																																										
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2015	City Express	Body	Instrument Cluster																																																										
M	2015	City Express	Body	Tire Pressure Indicator Module																																																										
M	2015	City Express	Body	Radio																																																									
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																										
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																										
M	2016	City Express	Chassis	Electronic Brake Control Module																																																										
M	2016	City Express	Chassis	Power Steering Control Module																																																										
M	2016	City Express	Body	Body Control Module																																																									
M	2016	City Express	Body	Underhood Fuse Block																																																										
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
M	2016	City Express	Body	Instrument Cluster																																																										
M	2016	City Express	Body	Tire Pressure Indicator Module																																																										
M	2016	City Express	Body	Radio																																																									
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2011	Orlando	Chassis	Parking Brake Control Module																																																										
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2011	Orlando	Chassis	Power Steering Control Module																																																										
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
P	2011	Orlando	Body	Body Control Module																																																											
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2011	Orlando	Body	Instrument Cluster																																																											
P	2011	Orlando	Body	Trailer Interface Control Module																																																											
P	2011	Orlando	Body	Radio																																																											
P	2011	Orlando	Body	Multimedia Player Interface Module																																																											
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2011	Orlando	Body	Keyless Entry Control Module																																																											
P	2011	Orlando	Body	Parking Assist Control Module																																																											
P	2011	Orlando	Body	Steering Column Lock Control Module																																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																											
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2012	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2012	Orlando	Chassis	Parking Brake Control Module																																																											
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2012	Orlando	Chassis	Power Steering Control Module																																																											
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2012	Orlando	Body	Body Control Module																																																											
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2012	Orlando	Body	Instrument Cluster																																																											
P	2012	Orlando	Body	Trailer Interface Control Module																																																											
P	2012	Orlando	Body	Radio																																																											
P	2012	Orlando	Body	Multimedia Player Interface Module																																																											
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2012	Orlando	Body	Keyless Entry Control Module																																																											
P	2012	Orlando	Body	Parking Assist Control Module																																																											
P	2012	Orlando	Body	Steering Column Lock Control Module																																																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																												
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																												
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																												
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																												
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																												
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																												
P	2013	Orlando	Chassis	Parking Brake Control Module																																																												
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2013	Orlando	Chassis	Power Steering Control Module																																																												
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2013	Orlando	Body	Body Control Module																																																												
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2013	Orlando	Body	Instrument Cluster																																																												
P	2013	Orlando	Body	Radio																																																											
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																											
P	2013	Orlando	Body	Multimedia Player Interface Module																																																											
P	2013	Orlando	Body	Mobile Telephone Control Module																																																											
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																											
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																											
P	2013	Orlando	Body	Front Seat Heating Control Module																																																											
P	2013	Orlando	Body	Keyless Entry Control Module																																																											
P	2013	Orlando	Body	Parking Assist Control Module																																																											
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																											
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																											
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
P	2014	Orlando	Chassis	Power Steering Control Module																																																											
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2014	Orlando	Body	Body Control Module																																																											
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2014	Orlando	Body	Instrument Cluster																																																											
P	2014	Orlando	Body	Radio																																																											
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																											
P	2014	Orlando	Body	Multimedia Player Interface Module																																																											
P	2014	Orlando	Body	Mobile Telephone Control Module																																																											
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																											
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																											
P	2014	Orlando	Body	Front Seat Heating Control Module																																																											
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																											
P	2014	Orlando	Body	Keyless Entry Control Module																																																											
P	2014	Orlando	Body	Parking Assist Control Module																																																											
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																											
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																											
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																											
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2015	Orlando	Chassis	Power Steering Control Module																																																											
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2015	Orlando	Body	Body Control Module																																																											
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2015	Orlando	Body	Instrument Cluster																																																											
P	2015	Orlando	Body	Radio																																																											
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																											
P	2015	Orlando	Body	Mobile Telephone Control Module																																																											
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																											
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																											
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																											
P	2015	Orlando	Body	Front Seat Heating Control Module																																																											
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																											
P	2015	Orlando	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
P	2015	Orlando	Body	Parking Assist Control Module																																																										
P	2015	Orlando	Body	Frontview Camera Module																																																										
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																										
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																										
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2016	Orlando	Chassis	Power Steering Control Module																																																										
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2016	Orlando	Body	Body Control Module																																																										
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2016	Orlando	Body	Instrument Cluster																																																										
P	2016	Orlando	Body	Radio																																																										
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																										
P	2016	Orlando	Body	Multimedia Player Interface Module																																																										
P	2016	Orlando	Body	Mobile Telephone Control Module																																																										
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																																										
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
P	2016	Orlando	Body	Front Seat Heating Control Module																																																										
P	2016	Orlando	Body	Rear Seat Heating Control Module																																																										
P	2016	Orlando	Body	Keyless Entry Control Module																																																										
P	2016	Orlando	Body	Parking Assist Control Module																																																										
P	2016	Orlando	Body	Frontview Camera Module																																																										
U	2004	ALL	Powertrain	Engine Control Module																																								V																	
U	2004	ALL	Powertrain	Transmission Control Module																																																										
U	2004	ALL	Body	Digital Radio Receiver																																																										
U	2004	ALL	Body	Driver Information Center																																																									
U	2004	ALL	Body	Instrument Panel Cluster																																																										
U	2004	ALL	Body	Radio																																																										
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2004	ALL	Body	Vehicle Theft Deterrent																																																										
U	2005	ALL	Powertrain	Engine Control Module																																								V																	
U	2005	ALL	Powertrain	Transmission Control Module																																																										
U	2005	ALL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
U	2005	ALL	Body	Body Control Module																																																												
U	2005	ALL	Body	Disc Player and Video																																																												
U	2005	ALL	Body	Digital Radio Receiver																																																												
U	2005	ALL	Body	HVAC Control Module																																																												
U	2005	ALL	Body	Instrument Panel Cluster																																																												
U	2005	ALL	Body	Left Power Sliding Door Module																																																												
U	2005	ALL	Body	Mobile Digital Media																																																												
U	2005	ALL	Body	Navigation Radio																																																												
U	2005	ALL	Body	Navigation Radio																																																												
U	2005	ALL	Body	Radio																																																												
U	2005	ALL	Body	Right Power Sliding Door Module																																																												
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																										V																		
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																												
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																												
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																												
U	2006	ALL	Chassis	Electronic Brake Control Module																																																												
U	2006	ALL	Body	Body Control Module																																																												
U	2006	ALL	Body	Disc Player and Video																																																												
U	2006	ALL	Body	Digital Radio Receiver																																																												
U	2006	ALL	Body	HVAC Control Module																																																												
U	2006	ALL	Body	Instrument Panel Cluster																																																												
U	2006	ALL	Body	Left Power Sliding Door Module																																																												
U	2006	ALL	Body	Mobile Digital Media																																																												
U	2006	ALL	Body	Navigation Radio																																																												
U	2006	ALL	Body	Navigation Radio																																																												
U	2006	ALL	Body	Radio																																																												
U	2006	ALL	Body	Right Power Sliding Door Module																																																												
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																												
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																												
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																												
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																												
U	2007	ALL	Chassis	Electronic Brake Control Module																																																												
U	2007	ALL	Body	Body Control Module																																																												
U	2007	ALL	Body	Digital Radio Receiver																																																												
U	2007	ALL	Body	Disc Player and Video Display																																																												
U	2007	ALL	Body	HVAC Control Module																																																												
U	2007	ALL	Body	Left Power Sliding Door Module																																																												
U	2007	ALL	Body	Mobile Digital Media																																																												
U	2007	ALL	Body	Radio																																																												
U	2007	ALL	Body	Navigation Radio																																																												
U	2007	ALL	Body	Right Power Sliding Door Module																																																												
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																												
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																												
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																												
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																												
U	2008	ALL	Chassis	Electronic Brake Control Module																																																												
U	2008	ALL	Body	Body Control Module																																																												
U	2008	ALL	Body	Digital Radio Receiver																																																												
U	2008	ALL	Body	Disc Player and Video Display																																																												
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																										
U	2008	ALL	Body	Left Power Sliding Door Module																																																											
U	2008	ALL	Body	Radio																																																										
U	2008	ALL	Body	Navigation Radio																																																										
U	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
U	2008	ALL	Body	Right Power Sliding Door Module																																																										
U	2009	ALL	Powertrain	Engine Control Module																																																										
U	2009	ALL	Powertrain	Transmission Control Module																																																										
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																										
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																										
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																										
U	2009	ALL	Body	Body Control Module																																																										
U	2009	ALL	Body	Digital Radio Receiver																																																										
U	2009	ALL	Body	Disc Player and Video Display																																																										
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																																										
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																										
U	2009	ALL	Body	Instrument Panel Cluster																																																										
U	2009	ALL	Body	Left Power Sliding Door Module																																																										
U	2009	ALL	Body	Radio																																																										
U	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
U	2009	ALL	Body	Right Power Sliding Door Module																																																										
V	2004	ALL	Powertrain	Engine Data Display																																								V																	
V	2004	ALL	Powertrain	Transmission Data Display																																																										
V	2004	ALL	Body	Digital Radio Receiver																																																										
V	2004	ALL	Body	Driver Information Center																																																									
V	2004	ALL	Body	Instrument Panel Cluster																																																										
V	2004	ALL	Body	Radio																																																										
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2004	ALL	Body	Vehicle Theft Deterrent																																																										
V	2005	Venture	Powertrain	Engine Control Module																																								V																	
V	2005	Venture	Powertrain	Transmission Control Module																																																										
V	2005	Venture	Body	Digital Radio Receiver																																																										
V	2005	Venture	Body	Driver Information Center																																																										
V	2005	Venture	Body	Instrument Panel Cluster																																																										
V	2005	Venture	Body	Radio																																																										
V	2005	Venture	Body	Supplemental Inflatable Restraint																																																										
V	2005	Venture	Body	Vehicle Theft Deterrent																																																										
V	2005	Uplander	Powertrain	Engine Control Module																																								V																	
V	2005	Uplander	Powertrain	Transmission Control Module																																																										
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																										
V	2005	Uplander	Body	Body Control Module																																																										
V	2005	Uplander	Body	Disc Player and Video																																																										
V	2005	Uplander	Body	Digital Radio Receiver																																																										
V	2005	Uplander	Body	HVAC Control Module																																																										
V	2005	Uplander	Body	Instrument Panel Cluster																																																										
V	2005	Uplander	Body	Left Power Sliding Door Module																																																										
V	2005	Uplander	Body	Mobile Digital Media																																																										
V	2005	Uplander	Body	Navigation Radio																																																										
V	2005	Uplander	Body	Navigation Radio																																																										
V	2005	Uplander	Body	Radio																																																										
V	2005	Uplander	Body	Right Power Sliding Door Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
V	2005	Uplander	Body	Supplemental Inflatable Restraint																																																									
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																									V																
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																									
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																									
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																									
V	2006	ALL	Chassis	Electronic Brake Control Module																																																									
V	2006	ALL	Body	Body Control Module																																																									
V	2006	ALL	Body	Disc Player and Video																																																									
V	2006	ALL	Body	Digital Radio Receiver																																																									
V	2006	ALL	Body	HVAC Control Module																																																									
V	2006	ALL	Body	Instrument Panel Cluster																																																									
V	2006	ALL	Body	Left Power Sliding Door Module																																																									
V	2006	ALL	Body	Mobile Digital Media																																																									
V	2006	ALL	Body	Navigation Radio																																																									
V	2006	ALL	Body	Navigation Radio																																																									
V	2006	ALL	Body	Radio																																																									
V	2006	ALL	Body	Right Power Sliding Door Module																																																									
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																									
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																									
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																									
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																									
V	2007	ALL	Chassis	Electronic Brake Control Module																																																									
V	2007	ALL	Body	Body Control Module																																																									
V	2007	ALL	Body	Digital Radio Receiver																																																									
V	2007	ALL	Body	Disc Player and Video Display																																																									
V	2007	ALL	Body	HVAC Control Module																																																									
V	2007	ALL	Body	Left Power Sliding Door Module																																																									
V	2007	ALL	Body	Mobile Digital Media																																																									
V	2007	ALL	Body	Radio																																																									
V	2007	ALL	Body	Navigation Radio																																																									
V	2007	ALL	Body	Right Power Sliding Door Module																																																									
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																									
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																									
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																									
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																									
V	2008	ALL	Chassis	Electronic Brake Control Module																																																									
V	2008	ALL	Body	Body Control Module																																																									
V	2008	ALL	Body	Digital Radio Receiver																																																									
V	2008	ALL	Body	Disc Player and Video Display																																																									
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																																									
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																									
V	2008	ALL	Body	Left Power Sliding Door Module																																																									
V	2008	ALL	Body	Radio																																																									
V	2008	ALL	Body	Navigation Radio																																																									
V	2008	ALL	Body	Remote Control Door Lock Receiver																																																									
V	2008	ALL	Body	Right Power Sliding Door Module																																																									
V	2009	ALL	Powertrain	Engine Control Module																																																									
V	2009	ALL	Powertrain	Transmission Control Module																																																									
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																									
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																									
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
V	2009	ALL	Body	Body Control Module																																																										
V	2009	ALL	Body	Digital Radio Receiver																																																										
V	2009	ALL	Body	Disc Player and Video Display																																																										
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																																										
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																										
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																										
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																										
V	2009	ALL	Body	Left Power Sliding Door Module																																																										
V	2009	ALL	Body	Radio																																																										
V	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
V	2009	ALL	Body	Right Power Sliding Door Module																																																										
X	2004	ALL	Powertrain	Engine Control Module																																								V																	
X	2004	ALL	Powertrain	Transmission Control Module																																																										
X	2004	ALL	Body	Digital Radio Receiver																																																										
X	2004	ALL	Body	Driver Information Center																																																										
X	2004	ALL	Body	Instrument Panel Cluster																																																										
X	2004	ALL	Body	Radio																																																										
X	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
X	2004	ALL	Body	Vehicle Theft Deterrent																																																										
X	2005	ALL	Powertrain	Engine Control Module																																								V																	
X	2005	ALL	Powertrain	Transmission Control Module																																																										
X	2005	ALL	Chassis	Electronic Brake Control Module																																																										
X	2005	ALL	Body	Body Control Module																																																										
X	2005	ALL	Body	Disc Player and Video																																																										
X	2005	ALL	Body	Digital Radio Receiver																																																										
X	2005	ALL	Body	HVAC Control Module																																																										
X	2005	ALL	Body	Instrument Panel Cluster																																																										
X	2005	ALL	Body	Left Power Sliding Door Module																																																										
X	2005	ALL	Body	Mobile Digital Media																																																										
X	2005	ALL	Body	Navigation Radio																																																										
X	2005	ALL	Body	Navigation Radio																																																										
X	2005	ALL	Body	Radio																																																										
X	2005	ALL	Body	Right Power Sliding Door Module																																																										
X	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																								V																	
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
X	2006	ALL	Chassis	Electronic Brake Control Module																																																										
X	2006	ALL	Body	Body Control Module																																																										
X	2006	ALL	Body	Disc Player and Video																																																										
X	2006	ALL	Body	Digital Radio Receiver																																																										
X	2006	ALL	Body	HVAC Control Module																																																										
X	2006	ALL	Body	Instrument Panel Cluster																																																										
X	2006	ALL	Body	Left Power Sliding Door Module																																																										
X	2006	ALL	Body	Mobile Digital Media																																																										
X	2006	ALL	Body	Navigation Radio																																																										
X	2006	ALL	Body	Navigation Radio																																																										
X	2006	ALL	Body	Radio																																																										
X	2006	ALL	Body	Right Power Sliding Door Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																									
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																									
A	2006	ALL	Powertrain	Transmission Control Module																																																									
A	2006	ALL	Chassis	Electronic Brake Control Module																																																									
A	2006	ALL	Chassis	Power Steering Control Module																																																									
A	2006	ALL	Body	Body Control Module																																																									
A	2006	ALL	Body	Digital Radio Receiver																																																									
A	2006	ALL	Body	Instrument Panel Cluster																																																									
A	2006	ALL	Body	Radio																																																									
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2006	ALL	Body	Theft Deterrent Module																																																									
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																									
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																									
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																									
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																									
A	2007	ALL	Chassis	Electronic Brake Control Module																																																									
A	2007	ALL	Chassis	Power Steering Control Module																																																									
A	2007	ALL	Body	Body Control Module																																																									
A	2007	ALL	Body	Digital Radio Receiver																																																									
A	2007	ALL	Body	Instrument Panel Cluster																																																									
A	2007	ALL	Body	Radio																																																									
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
A	2007	ALL	Body	Theft Deterrent Module																																																									
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																									
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																									
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																									
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																									
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																									
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																									
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES																																																									
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES																																																									
A	2008	HHR	Chassis	Power Steering Control Module																																																									
A	2008	HHR	Chassis	Power Steering Control Module																																																									
A	2008	HHR	Body	Body Control Module																																																									
A	2008	HHR	Body	Digital Radio Receiver																																																									
A	2008	HHR	Body	Instrument Panel Cluster																																																									
A	2008	HHR	Body	Radio																																																									
A	2008	HHR	Body	Supplemental Inflatable Restraint																																																									
A	2008	HHR	Body	Theft Deterrent Module																																																									
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																									
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																									
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																									
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																									
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																									
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																									
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																									
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																									
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																									
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																									
A	2008	HHR Panel	Body	Body Control Module																																																									
A	2008	HHR Panel	Body	Digital Radio Receiver																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																									
A	2008	HHR Panel	Body	Radio																																																									
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2008	HHR Panel	Body	Theft Deterrent Module																																																										
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																																										
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2009	HHR	Chassis	Power Steering Control Module																																																										
A	2009	HHR	Chassis	Power Steering Control Module																																																										
A	2009	HHR	Body	Body Control Module																																																										
A	2009	HHR	Body	Digital Radio Receiver																																																										
A	2009	HHR	Body	Instrument Panel Cluster																																																										
A	2009	HHR	Body	Radio																																																										
A	2009	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2009	HHR	Body	Theft Deterrent Module																																																										
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2009	HHR Panel	Body	Body Control Module																																																										
A	2009	HHR Panel	Body	Digital Radio Receiver																																																										
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2009	HHR Panel	Body	Radio																																																										
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2009	HHR Panel	Body	Theft Deterrent Module																																																										
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																										
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2010	HHR	Chassis	Power Steering Control Module																																																										
A	2010	HHR	Chassis	Power Steering Control Module																																																										
A	2010	HHR	Body	Body Control Module																																																										
A	2010	HHR	Body	Digital Radio Receiver																																																										
A	2010	HHR	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2010	HHR	Body	Radio																																																								
A	2010	HHR	Body	Supplemental Inflatable Restraint																																																								
A	2010	HHR	Body	Theft Deterrent Module																																																								
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																								
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																								
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																								
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																								
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																								
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																								
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																								
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																								
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																								
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																								
A	2010	HHR Panel	Body	Body Control Module																																																								
A	2010	HHR Panel	Body	Digital Radio Receiver																																																								
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																								
A	2010	HHR Panel	Body	Radio																																																								
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																																								
A	2010	HHR Panel	Body	Theft Deterrent Module																																																								
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																								
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																								
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																								
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																								
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																																								
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																																								
A	2011	HHR	Chassis	Power Steering Control Module																																																								
A	2011	HHR	Body	Body Control Module																																																								
A	2011	HHR	Body	Digital Radio Receiver																																																								
A	2011	HHR	Body	Instrument Panel Cluster																																																								
A	2011	HHR	Body	Radio																																																								
A	2011	HHR	Body	Supplemental Inflatable Restraint																																																								
A	2011	HHR	Body	Theft Deterrent Module																																																								
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																								
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																								
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																								
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																								
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																								
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																								
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																								
A	2011	HHR Panel	Body	Body Control Module																																																								
A	2011	HHR Panel	Body	Digital Radio Receiver																																																								
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																								
A	2011	HHR Panel	Body	Radio																																																								
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																																								
A	2011	HHR Panel	Body	Theft Deterrent Module																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																							
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																							
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																							
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																							
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																							
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																						
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																						
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																						
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																						
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																						
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																						
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																						
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																						
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																						
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																						
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																						
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																						
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																						
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																						
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																						
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																						
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																						
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																						
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																											V											
A	2013	Trax	Chassis	Electronic Brake Control Module																																																						
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																						
A	2013	Trax	Chassis	Power Steering Control Module																																																						
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																						
A	2013	Trax	Body	Body Control Module																																																					
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																					
A	2013	Trax	Body	Passenger Presence Module																																																					
A	2013	Trax	Body	Instrument Cluster																																																					
A	2013	Trax	Body	Radio																																																					
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																					
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																					
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																					
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																					
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																					
A	2013	Trax	Body	Front Seat Heating Control Module																																																					
A	2013	Trax	Body	Parking Assist Control Module																																																					
A	2013	Trax	Body	Frontview Camera Module																																																					
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																					
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																					
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																					
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																					
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																					
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																					
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																					
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																					
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																					
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																					

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																									
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																									
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																									
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																									
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																									
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																									
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																												V													
A	2014	Trax	Chassis	Electronic Brake Control Module																																																									
A	2014	Trax	Chassis	Power Steering Control Module																																																									
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2014	Trax	Body	Body Control Module																																																									
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2014	Trax	Body	Passenger Presence Module																																																									
A	2014	Trax	Body	Instrument Cluster																																																									
A	2014	Trax	Body	Radio																																																									
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																									
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																									
A	2014	Trax	Body	Front Seat Heating Control Module																																																									
A	2014	Trax	Body	Parking Assist Control Module																																																									
A	2014	Trax	Body	Frontview Camera Module																																																									
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																									
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																									
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																									
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																									
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																									
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																									
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																									
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																									
A	2015	Trax	Powertrain	Chassis Control Module																																																									
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																												V													
A	2015	Trax	Chassis	Electronic Brake Control Module																																																									
A	2015	Trax	Chassis	Power Steering Control Module																																																									
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2015	Trax	Body	Body Control Module																																																								
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2015	Trax	Body	Passenger Presence Module																																																									
A	2015	Trax	Body	Instrument Cluster																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2015	Trax	Body	Radio																																																								
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																								
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
A	2015	Trax	Body	Seat Memory Control Module																																																								
A	2015	Trax	Body	Front Seat Heating Control Module																																																								
A	2015	Trax	Body	Right Side Object Detection Control Module																																																								
A	2015	Trax	Body	Left Side Object Detection Control Module																																																								
A	2015	Trax	Body	Parking Assist Control Module																																																								
A	2015	Trax	Body	Frontview Camera Module																																																								
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																								
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																								
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																								
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																								
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																								
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																								
A	2016	Trax	Powertrain	Chassis Control Module																																																								
A	2016	Trax	Chassis	Electronic Brake Control Module																																																								
A	2016	Trax	Chassis	Power Steering Control Module																																																								
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2016	Trax	Body	Body Control Module																																																								
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2016	Trax	Body	Passenger Presence Module																																																								
A	2016	Trax	Body	Instrument Cluster																																																								
A	2016	Trax	Body	Trailer Interface Control Module																																																								
A	2016	Trax	Body	Radio																																																								
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																								
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
A	2016	Trax	Body	Seat Memory Control Module																																																								
A	2016	Trax	Body	Front Seat Heating Control Module																																																								
A	2016	Trax	Body	Right Side Object Detection Control Module																																																								
A	2016	Trax	Body	Left Side Object Detection Control Module																																																								
A	2016	Trax	Body	Parking Assist Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2016	Trax	Body	Frontview Camera Module																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																				V																																				
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																				V																																				
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																				
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																				V																																				
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																				
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																								
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																								
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																								
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																								
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																								
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
C	2004	ALL	Chassis	ESC																																																								
C	2004	ALL	Chassis	Rear Wheel Steering																																																								
C	2004	ALL	Chassis	Tire Pressure Monitor																																																	V							
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																								
C	2004	ALL	Chassis	VSES																																																								
C	2004	ALL	Body	Amplifier (Bose)																							V																																	
C	2004	ALL	Body	Body Control Module																																																								
C	2004	ALL	Body	CD Changer																																																								
C	2004	ALL	Body	Chime																																																								
C	2004	ALL	Body	Driver Door Module																																																								
C	2004	ALL	Body	Driver Seat Module																								V																										V						
C	2004	ALL	Body	Heating and Air Conditioning Auto																								V																											V	V				
C	2004	ALL	Body	Heating and Air Conditioning Manual																								V																											V	V				
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																								V																											V	V				
C	2004	ALL	Body	Instrument Panel Cluster																V	V							V																																

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2004	ALL	Body	OnStar																																																									
C	2004	ALL	Body	Passenger Door Module																																																									
C	2004	ALL	Body	Passenger Presence System																																																									
C	2004	ALL	Body	Radio Base																																																									
C	2004	ALL	Body	Radio Uplevel																																																									
C	2004	ALL	Body	Radio Navigation																																																									
C	2004	ALL	Body	Rear Aux. Climate Module																								V																													V				V
C	2004	ALL	Body	Rear HVAC																																																									
C	2004	ALL	Body	Rear Seat Audio																																																									
C	2004	ALL	Body	Rear Seat Entertainment																																																									
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
C	2004	ALL	Body	Vehicle Theft Deterrent																																																									
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																				V																																					
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																					
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																				V																																					
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																				V																																					
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																					
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																					
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																				V																																					
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																					
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																									
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																									
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																									
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
C	2005	ALL	Chassis	ESC																																																									
C	2005	ALL	Chassis	Rear Wheel Steering																																																									
C	2005	ALL	Chassis	Tire Pressure Monitor																																																									
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2005	ALL	Chassis	VSES																																																								
C	2005	ALL	Body	Amplifier (Bose)																							V																																	
C	2005	ALL	Body	Body Control Module																																																								
C	2005	ALL	Body	CD Changer																																																								
C	2005	ALL	Body	Chime																																																								
C	2005	ALL	Body	Disc Player and Video Display																																																								
C	2005	ALL	Body	Driver Door Module																																																								
C	2005	ALL	Body	Driver Seat Module																								V																											V					
C	2005	ALL	Body	Generator Battery Control Module																																																								
C	2005	ALL	Body	Heating and Air Conditioning Auto																								V																												V	V			
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																								V																												V	V			
C	2005	ALL	Body	Heating and Air Conditioning Manual																								V																												V	V			
C	2005	ALL	Body	Instrument Panel Cluster																V	V							V																																
C	2005	ALL	Body	Passenger Door Module																																																						V	V	
C	2005	ALL	Body	Passenger Presence System																																																								V
C	2005	ALL	Body	Base Radio																																																								
C	2005	ALL	Body	Uplevel Radio																																																								
C	2005	ALL	Body	Navigation Radio																																																								
C	2005	ALL	Body	Rear Aux. Climate Module																								V																												V					V
C	2005	ALL	Body	Rear HVAC																																																								
C	2005	ALL	Body	Rear Seat Audio																																																								
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																								
C	2005	ALL	Body	Vehicle Theft Deterrent																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																				V																																				
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																				V																																				
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																				V																																				
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																				
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																				V																																				
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																				
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																								
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																								
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																									
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																									
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																									
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
C	2006	ALL	Chassis	ESC																																																								
C	2006	ALL	Chassis	Tire Pressure Monitor																																															V									
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																								
C	2006	ALL	Chassis	VSES																																																								
C	2006	ALL	Body	Amplifier (Bose)																							V																																		
C	2006	ALL	Body	Body Control Module																																																								
C	2006	ALL	Body	CD Changer																																																								
C	2006	ALL	Body	Chime																																																								
C	2006	ALL	Body	Disc Player and Video Display																																																								
C	2006	ALL	Body	Driver Door Module																																																								
C	2006	ALL	Body	Driver Seat Module																								V																								V								
C	2006	ALL	Body	Generator Battery Control Module																																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto																								V																									V	V						
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																								V																									V	V						
C	2006	ALL	Body	Heating and Air Conditioning Manual																								V																									V	V						
C	2006	ALL	Body	Instrument Panel Cluster																V	V							V																																
C	2006	ALL	Body	Passenger Door Module																																																			V	V			
C	2006	ALL	Body	Passenger Presence System																																																					V		
C	2006	ALL	Body	Base Radio																																																							
C	2006	ALL	Body	Uplevel Radio																																																							
C	2006	ALL	Body	Navigation Radio																																																							
C	2006	ALL	Body	Rear Aux. Climate Module																								V																									V						V
C	2006	ALL	Body	Rear HVAC																																																							
C	2006	ALL	Body	Rear Seat Audio																																																							
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																							
C	2006	ALL	Body	Vehicle Theft Deterrent																																																							
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																							
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V	V																																													
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																	
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																													
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																	
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																													
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																	
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module					V						V																																													
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																	
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																								
C	2007	Avalanche	Body	Amplifier (Bose)																																																									
C	2007	Avalanche	Body	Assist Step Controller																																																									
C	2007	Avalanche	Body	Body Control Module																																																									
C	2007	Avalanche	Body	Body Control Module (aux.)																																																										
C	2007	Avalanche	Body	Digital Radio Receiver																																																										
C	2007	Avalanche	Body	Driver Door Switch																																																										
C	2007	Avalanche	Body	HVAC Control Module Auto									V																																																	
C	2007	Avalanche	Body	HVAC Control Module Manual																																																										
C	2007	Avalanche	Body	Instrument Panel Cluster																																																										
C	2007	Avalanche	Body	Memory Seat Module																																																										
C	2007	Avalanche	Body	Park Assist Module																																																										
C	2007	Avalanche	Body	Passenger Door Switch																																																										
C	2007	Avalanche	Body	Passenger Presence System																																																										
C	2007	Avalanche	Body	Radio																																																										
C	2007	Avalanche	Body	Rear Heated Seat Module																																																										
C	2007	Avalanche	Body	Rear HVAC/RSA																																																										
C	2007	Avalanche	Body	Rollover Sensor																																																										
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2007	Avalanche	Body	Theft Deterrent Module																																																										
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																															
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																			
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V	V																																															
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																			
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																															
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																			
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																															
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V	V																																															
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																			
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Suburban	Chassis	Electronic Suspension Control																																																										
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																										
C	2007	Suburban	Body	Amplifier (Bose)																																																										
C	2007	Suburban	Body	Assist Step Controller																																																										
C	2007	Suburban	Body	Body Control Module																																																										
C	2007	Suburban	Body	Body Control Module (aux.)																																																										
C	2007	Suburban	Body	Digital Radio Receiver																																																										
C	2007	Suburban	Body	Driver Door Switch																																																										
C	2007	Suburban	Body	HVAC Control Module Auto																																																										
C	2007	Suburban	Body	HVAC Control Module Manual																																																										
C	2007	Suburban	Body	Instrument Panel Cluster																																																										
C	2007	Suburban	Body	Lift Gate Module																																																										
C	2007	Suburban	Body	Memory Seat Module																																																										
C	2007	Suburban	Body	Park Assist Module																																																										
C	2007	Suburban	Body	Passenger Door Switch																																																										
C	2007	Suburban	Body	Passenger Presence System																																																										
C	2007	Suburban	Body	Radio																																																										
C	2007	Suburban	Body	Rear Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2007	Suburban	Body	Rear HVAC/RSA																																																								
C	2007	Suburban	Body	Rollover Sensor																																																								
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																																								
C	2007	Suburban	Body	Theft Deterrent Module																																																								
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module											V																																													
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																		
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																		
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																													
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V	V																																													
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																		
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																													
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																		
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V	V																																													
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																		
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																													
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module					V						V																																													
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																		
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module											V																																													
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2007	Silverado	Chassis	Electronic Suspension Control																																																								
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																								
C	2007	Silverado	Body	Amplifier (Bose)																																																								
C	2007	Silverado	Body	Body Control Module																																																								
C	2007	Silverado	Body	Body Control Module (aux.)																																																								
C	2007	Silverado	Body	Digital Radio Receiver																																																								
C	2007	Silverado	Body	Driver Door Switch																																																								
C	2007	Silverado	Body	HVAC Control Module Auto									V																																															
C	2007	Silverado	Body	HVAC Control Module Manual																																																								
C	2007	Silverado	Body	Instrument Panel Cluster																																																								
C	2007	Silverado	Body	Memory Seat Module																																																								
C	2007	Silverado	Body	Park Assist Module																																																								
C	2007	Silverado	Body	Passenger Door Switch																																																								
C	2007	Silverado	Body	Passenger Presence System																																																								
C	2007	Silverado	Body	Radio																																																								
C	2007	Silverado	Body	Rear Heated Seat Module																																																								
C	2007	Silverado	Body	Rear HVAC/RSA																																																								
C	2007	Silverado	Body	Rollover Sensor																																																								
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																																								
C	2007	Silverado	Body	Theft Deterrent Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																			
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																														
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																			
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																														
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																			
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																								
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																								
C	2007	Tahoe	Body	Amplifier (Bose)																																																								
C	2007	Tahoe	Body	Assist Step Controller																																																								
C	2007	Tahoe	Body	Body Control Module																																																								
C	2007	Tahoe	Body	Body Control Module (aux.)																																																								
C	2007	Tahoe	Body	Digital Radio Receiver																																																								
C	2007	Tahoe	Body	Driver Door Switch																																																								
C	2007	Tahoe	Body	HVAC Control Module Auto																																																								
C	2007	Tahoe	Body	HVAC Control Module Manual																																																								
C	2007	Tahoe	Body	Instrument Panel Cluster																																																								
C	2007	Tahoe	Body	Lift Gate Module																																																								
C	2007	Tahoe	Body	Memory Seat Module																																																								
C	2007	Tahoe	Body	Park Assist Module																																																								
C	2007	Tahoe	Body	Passenger Door Switch																																																								
C	2007	Tahoe	Body	Passenger Presence System																																																								
C	2007	Tahoe	Body	Radio																																																								
C	2007	Tahoe	Body	Rear Heated Seat Module																																																								
C	2007	Tahoe	Body	Rear HVAC/RSA																																																								
C	2007	Tahoe	Body	Rollover Sensor																																																								
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																								
C	2007	Tahoe	Body	Theft Deterrent Module																																																								
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																			
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																			
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																															
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																			
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																															
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																			
C	2008	Avalanche	Chassis	Electronic Brake Control Module																																																									
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																									
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																									
C	2008	Avalanche	Body	Amplifier (Bose)																																																								
C	2008	Avalanche	Body	Assist Step Controller																																																								
C	2008	Avalanche	Body	Body Control Module																																																								
C	2008	Avalanche	Body	Body Control Module (aux.)																																																								
C	2008	Avalanche	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2008	Avalanche	Body	Driver Door Switch																																																								
C	2008	Avalanche	Body	HVAC Control Module Auto									V																																																
C	2008	Avalanche	Body	HVAC Control Module Manual																																																										
C	2008	Avalanche	Body	Instrument Panel Cluster																																																										
C	2008	Avalanche	Body	Memory Seat Module																																																										
C	2008	Avalanche	Body	Park Assist Module																																																										
C	2008	Avalanche	Body	Passenger Door Switch																																																										
C	2008	Avalanche	Body	Passenger Presence System																																																										
C	2008	Avalanche	Body	Radio																																																										
C	2008	Avalanche	Body	Rear Heated Seat Module																																																										
C	2008	Avalanche	Body	Rear HVAC/RSA																																																										
C	2008	Avalanche	Body	Rollover Sensor																																																										
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2008	Avalanche	Body	Theft Deterrent Module																																																										
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																															
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																			
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																			
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																			
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																															
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																			
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2008	Suburban	Chassis	Electronic Suspension Control																																																										
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																										
C	2008	Suburban	Body	Amplifier (Bose)																																																										
C	2008	Suburban	Body	Assist Step Controller																																																										
C	2008	Suburban	Body	Body Control Module																																																										
C	2008	Suburban	Body	Body Control Module (aux.)																																																										
C	2008	Suburban	Body	Digital Radio Receiver																																																										
C	2008	Suburban	Body	Driver Door Switch																																																										
C	2008	Suburban	Body	HVAC Control Module Auto									V																																																	
C	2008	Suburban	Body	HVAC Control Module Manual																																																										
C	2008	Suburban	Body	Instrument Panel Cluster																																																										
C	2008	Suburban	Body	Lift Gate Module																																																										
C	2008	Suburban	Body	Memory Seat Module																																																										
C	2008	Suburban	Body	Park Assist Module																																																										
C	2008	Suburban	Body	Passenger Door Switch																																																										
C	2008	Suburban	Body	Passenger Presence System																																																										
C	2008	Suburban	Body	Radio																																																										
C	2008	Suburban	Body	Rear Heated Seat Module																																																										
C	2008	Suburban	Body	Rear HVAC/RSA																																																										
C	2008	Suburban	Body	Rollover Sensor																																																										
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2008	Suburban	Body	Theft Deterrent Module																																																								
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																			
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																														
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																			
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																			
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																			
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																															
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																			
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V	V																																														
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																			
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																														
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																															
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																			
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module											V																																														
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2008	Silverado	Chassis	Electronic Suspension Control																																																									
C	2008	Silverado	Chassis	Trailer Brake Control Module																																																									
C	2008	Silverado	Body	Amplifier (Bose)																																																									
C	2008	Silverado	Body	Body Control Module																																																									
C	2008	Silverado	Body	Body Control Module (aux.)																																																									
C	2008	Silverado	Body	Digital Radio Receiver																																																									
C	2008	Silverado	Body	Driver Door Switch																																																									
C	2008	Silverado	Body	HVAC Control Module Auto									V																																																
C	2008	Silverado	Body	HVAC Control Module Manual																																																									
C	2008	Silverado	Body	Instrument Panel Cluster																																																									
C	2008	Silverado	Body	Memory Seat Module																																																									
C	2008	Silverado	Body	Park Assist Module																																																									
C	2008	Silverado	Body	Passenger Door Switch																																																									
C	2008	Silverado	Body	Passenger Presence System																																																									
C	2008	Silverado	Body	Radio																																																									
C	2008	Silverado	Body	Rear Heated Seat Module																																																									
C	2008	Silverado	Body	Rear HVAC/RSA																																																									
C	2008	Silverado	Body	Rollover Sensor																																																									
C	2008	Silverado	Body	Supplemental Inflatable Restraint																																																									
C	2008	Silverado	Body	Theft Deterrent Module																																																									
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																																									
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																														
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																			

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																														
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																			
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																														
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																			
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
C	2008	Tahoe	Chassis	Electronic Brake Control Module																																																									
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																									
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																									
C	2008	Tahoe	Body	Amplifier (Bose)																																																									
C	2008	Tahoe	Body	Assist Step Controller																																																									
C	2008	Tahoe	Body	Body Control Module																																																									
C	2008	Tahoe	Body	Body Control Module (aux.)																																																									
C	2008	Tahoe	Body	Digital Radio Receiver																																																									
C	2008	Tahoe	Body	Driver Door Switch																																																									
C	2008	Tahoe	Body	HVAC Control Module Auto									V																																																
C	2008	Tahoe	Body	HVAC Control Module Manual																																																									
C	2008	Tahoe	Body	Instrument Panel Cluster																																																									
C	2008	Tahoe	Body	Memory Seat Module																																																									
C	2008	Tahoe	Body	Park Assist Module																																																									
C	2008	Tahoe	Body	Passenger Presence System																																																									
C	2008	Tahoe	Body	Radio																																																									
C	2008	Tahoe	Body	Rear Heated Seat Module																																																									
C	2008	Tahoe	Body	Rear HVAC/RSA																																																									
C	2008	Tahoe	Body	Rollover Sensor																																																									
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																									
C	2008	Tahoe	Body	Theft Deterrent Module																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																				
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																									
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
C	2008	Tahoe Hybrid	Body	Body Control Module																																																									
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																																									
C	2008	Tahoe Hybrid	Body	HVAC Control Module									V																																															
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
C	2008	Tahoe Hybrid	Body	Memory Seat Module																																																									
C	2008	Tahoe Hybrid	Body	Park Assist Module																																																									
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2008	Tahoe Hybrid	Body	Radio																																																								
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																																								
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																														
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																								
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																														
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
C	2009	Avalanche	Chassis	Electronic Brake Control Module																																																								
C	2009	Avalanche	Chassis	Electronic Suspension Control																																																								
C	2009	Avalanche	Chassis	Trailer Brake Control Module																																																								
C	2009	Avalanche	Body	Amplifier (Bose)																																																								
C	2009	Avalanche	Body	Assist Step Controller																																																								
C	2009	Avalanche	Body	Body Control Module																																																								
C	2009	Avalanche	Body	Body Control Module (aux.)																																																								
C	2009	Avalanche	Body	Digital Radio Receiver																																																								
C	2009	Avalanche	Body	Driver Door Switch																																																								
C	2009	Avalanche	Body	HVAC Control Module Auto									V																																															
C	2009	Avalanche	Body	HVAC Control Module Manual																																																								
C	2009	Avalanche	Body	Instrument Panel Cluster																																																								
C	2009	Avalanche	Body	Memory Seat Module																																																								
C	2009	Avalanche	Body	Park Assist Module																																																								
C	2009	Avalanche	Body	Passenger Door Switch																																																								
C	2009	Avalanche	Body	Passenger Presence System																																																								
C	2009	Avalanche	Body	Radio																																																								
C	2009	Avalanche	Body	Rear Heated Seat Module																																																								
C	2009	Avalanche	Body	Rear HVAC/RSA																																																								
C	2009	Avalanche	Body	Rollover Sensor																																																								
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																								
C	2009	Avalanche	Body	Theft Deterrent Module																																																								
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																														
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																														
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																									
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																									
C	2009	Cheyenne	Body	Amplifier (Bose)																																																									
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																									
C	2009	Cheyenne	Body	Digital Radio Receiver																																																									
C	2009	Cheyenne	Body	Driver Door Switch																																																									
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																									
C	2009	Cheyenne	Body	Park Assist Module																																																									
C	2009	Cheyenne	Body	Passenger Door Switch																																																									
C	2009	Cheyenne	Body	Passenger Presence System																																																									
C	2009	Cheyenne	Body	Rear Heated Seat Module																																																									
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																									
C	2009	Cheyenne	Body	Rollover Sensor																																																									
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																									
C	2009	Cheyenne	Body	Theft Deterrent Module																																																									
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																														
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																															
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																															
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																										
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2009	Suburban	Chassis	Electronic Suspension Control																																																										
C	2009	Suburban	Chassis	Trailer Brake Control Module																																																										
C	2009	Suburban	Body	Amplifier (Bose)																																																										
C	2009	Suburban	Body	Assist Step Controller																																																										
C	2009	Suburban	Body	Body Control Module																																																									
C	2009	Suburban	Body	Body Control Module (aux.)																																																										
C	2009	Suburban	Body	Digital Radio Receiver																																																										
C	2009	Suburban	Body	Driver Door Switch																																																										
C	2009	Suburban	Body	HVAC Control Module Auto									V																																																
C	2009	Suburban	Body	HVAC Control Module Manual																																																										
C	2009	Suburban	Body	Instrument Panel Cluster																																																										
C	2009	Suburban	Body	Left Side Object Detection Module																																																										
C	2009	Suburban	Body	Lift Gate Module																																																										
C	2009	Suburban	Body	Memory Seat Module																																																										
C	2009	Suburban	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2009	Suburban	Body	Passenger Door Switch																																																								
C	2009	Suburban	Body	Passenger Presence System																																																								
C	2009	Suburban	Body	Radio																																																								
C	2009	Suburban	Body	Rear Heated Seat Module																																																								
C	2009	Suburban	Body	Rear HVAC/RSA																																																								
C	2009	Suburban	Body	Right Side Object Detection Module																																																								
C	2009	Suburban	Body	Rollover Sensor																																																								
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																																								
C	2009	Suburban	Body	Theft Deterrent Module																																																								
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																													
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																								
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																								
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																													
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																								
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																								
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																													
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																													
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																								
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																													
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																								
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
C	2009	Silverado	Chassis	Electronic Suspension Control																																																								
C	2009	Silverado	Chassis	Trailer Brake Control Module																																																								
C	2009	Silverado	Body	Amplifier (Bose)																																																								
C	2009	Silverado	Body	Body Control Module																																																								
C	2009	Silverado	Body	Body Control Module (aux.)																																																								
C	2009	Silverado	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2009	Silverado	Body	Driver Door Switch																																																									
C	2009	Silverado	Body	HVAC Control Module Auto									V																																																	
C	2009	Silverado	Body	HVAC Control Module Manual																																																											
C	2009	Silverado	Body	Instrument Panel Cluster																																																											
C	2009	Silverado	Body	Memory Seat Module																																																											
C	2009	Silverado	Body	Park Assist Module																																																											
C	2009	Silverado	Body	Passenger Door Switch																																																											
C	2009	Silverado	Body	Passenger Presence System																																																											
C	2009	Silverado	Body	Radio																																																											
C	2009	Silverado	Body	Rear Heated Seat Module																																																											
C	2009	Silverado	Body	Rear HVAC/RSA																																																											
C	2009	Silverado	Body	Rollover Sensor																																																											
C	2009	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2009	Silverado	Body	Theft Deterrent Module																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																						
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																											
C	2009	Silverado Hybrid	Body	Body Control Module																																																											
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																											
C	2009	Silverado Hybrid	Body	Driver Door Switch																																																											
C	2009	Silverado Hybrid	Body	HVAC Control Module									V																																																		
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
C	2009	Silverado Hybrid	Body	Memory Seat Module																																																											
C	2009	Silverado Hybrid	Body	Park Assist Module																																																											
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2009	Silverado Hybrid	Body	Passenger Presence System																																																											
C	2009	Silverado Hybrid	Body	Radio																																																											
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
C	2009	Silverado Hybrid	Body	Rollover Sensor																																																											
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																															
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																															
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																																										
C	2009	Tahoe	Body	Amplifier (Bose)																																																										
C	2009	Tahoe	Body	Assist Step Controller																																																										
C	2009	Tahoe	Body	Body Control Module																																																										
C	2009	Tahoe	Body	Body Control Module (aux.)																																																										
C	2009	Tahoe	Body	Digital Radio Receiver																																																										
C	2009	Tahoe	Body	Driver Door Switch																																																										
C	2009	Tahoe	Body	HVAC Control Module Auto									V																																																
C	2009	Tahoe	Body	HVAC Control Module Manual																																																										
C	2009	Tahoe	Body	Instrument Panel Cluster																																																										
C	2009	Tahoe	Body	Left Side Object Detection Module																																																										
C	2009	Tahoe	Body	Lift Gate Module																																																										
C	2009	Tahoe	Body	Memory Seat Module																																																										
C	2009	Tahoe	Body	Park Assist Module																																																										
C	2009	Tahoe	Body	Passenger Door Switch																																																										
C	2009	Tahoe	Body	Passenger Presence System																																																										
C	2009	Tahoe	Body	Radio																																																										
C	2009	Tahoe	Body	Rear Heated Seat Module																																																										
C	2009	Tahoe	Body	Rear HVAC/RSA																																																										
C	2009	Tahoe	Body	Right Side Object Detection Module																																																										
C	2009	Tahoe	Body	Rollover Sensor																																																										
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2009	Tahoe	Body	Theft Deterrent Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																					
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2009	Tahoe Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2009	Tahoe Hybrid	Body	HVAC Control Module									V																																																
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2009	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2009	Tahoe Hybrid	Body	Radio																																																										
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																										
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Avalanche	Chassis	Electronic Brake Control Module																																																										
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Avalanche	Body	Amplifier (Bose)																																																										
C	2010	Avalanche	Body	Assist Step Controller																																																										
C	2010	Avalanche	Body	Body Control Module																																																										
C	2010	Avalanche	Body	Body Control Module (aux.)																																																										
C	2010	Avalanche	Body	Digital Radio Receiver																																																										
C	2010	Avalanche	Body	Driver Door Switch																																																										
C	2010	Avalanche	Body	HVAC Control Module Auto									V																																																
C	2010	Avalanche	Body	HVAC Control Module Manual																																																										
C	2010	Avalanche	Body	Instrument Panel Cluster																																																										
C	2010	Avalanche	Body	Memory Seat Module																																																										
C	2010	Avalanche	Body	Park Assist Module																																																										
C	2010	Avalanche	Body	Passenger Door Switch																																																										
C	2010	Avalanche	Body	Passenger Presence System																																																										
C	2010	Avalanche	Body	Radio																																																										
C	2010	Avalanche	Body	Rear Heated Seat Module																																																										
C	2010	Avalanche	Body	Rear HVAC/RSA																																																										
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2010	Avalanche	Body	Theft Deterrent Module																																																										
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																									
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																									
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Cheyenne	Body	Amplifier (Bose)																																																									
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																									
C	2010	Cheyenne	Body	Digital Radio Receiver																																																									
C	2010	Cheyenne	Body	Driver Door Switch																																																									
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																									
C	2010	Cheyenne	Body	Park Assist Module																																																									
C	2010	Cheyenne	Body	Passenger Door Switch																																																									
C	2010	Cheyenne	Body	Passenger Presence System																																																									
C	2010	Cheyenne	Body	Rear Heated Seat Module																																																									
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																									
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																									
C	2010	Cheyenne	Body	Theft Deterrent Module																																																									
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
C	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																									
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2010	Suburban	Chassis	Electronic Suspension Control																																																									
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Suburban	Body	Amplifier (Bose)																																																									
C	2010	Suburban	Body	Assist Step Controller																																																									
C	2010	Suburban	Body	Body Control Module																																																									
C	2010	Suburban	Body	Body Control Module (aux.)																																																									
C	2010	Suburban	Body	Digital Radio Receiver																																																									
C	2010	Suburban	Body	Driver Door Switch																																																									
C	2010	Suburban	Body	HVAC Control Module Auto									V																																															
C	2010	Suburban	Body	HVAC Control Module Manual																																																									
C	2010	Suburban	Body	Instrument Panel Cluster																																																									
C	2010	Suburban	Body	Left Side Object Detection Module																																																									
C	2010	Suburban	Body	Lift Gate Module																																																									
C	2010	Suburban	Body	Memory Seat Module																																																									
C	2010	Suburban	Body	Park Assist Module																																																									
C	2010	Suburban	Body	Passenger Door Switch																																																									
C	2010	Suburban	Body	Passenger Presence System																																																									
C	2010	Suburban	Body	Radio																																																									
C	2010	Suburban	Body	Rear Heated Seat Module																																																									
C	2010	Suburban	Body	Rear HVAC/RSA																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2010	Suburban	Body	Right Side Object Detection Module																																																								
C	2010	Suburban	Body	Supplemental Inflatable Restraint																																																									
C	2010	Suburban	Body	Theft Deterrent Module																																																									
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																						V																			
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																						V																			
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																						V																			
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																						V																			
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																									
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
C	2010	Silverado	Chassis	Electronic Suspension Control																																																									
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
C	2010	Silverado	Body	Amplifier (Bose)																																																									
C	2010	Silverado	Body	Body Control Module																																																									
C	2010	Silverado	Body	Body Control Module (aux.)																																																									
C	2010	Silverado	Body	Digital Radio Receiver																																																									
C	2010	Silverado	Body	Driver Door Switch																																																									
C	2010	Silverado	Body	HVAC Control Module Auto									V																																															
C	2010	Silverado	Body	HVAC Control Module Manual									V																																															
C	2010	Silverado	Body	Instrument Panel Cluster																																																									
C	2010	Silverado	Body	Memory Seat Module																																																									
C	2010	Silverado	Body	Park Assist Module																																																									
C	2010	Silverado	Body	Passenger Door Switch																																																									
C	2010	Silverado	Body	Passenger Presence System																																																									
C	2010	Silverado	Body	Radio																																																									
C	2010	Silverado	Body	Rear Heated Seat Module																																																									
C	2010	Silverado	Body	Rear HVAC/RSA																																																									
C	2010	Silverado	Body	Supplemental Inflatable Restraint																																																									
C	2010	Silverado	Body	Theft Deterrent Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																				
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																									
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																									
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																									
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																									
C	2010	Silverado Hybrid	Body	Body Control Module																																																									
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																									
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																									
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																									
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																									
C	2010	Silverado Hybrid	Body	HVAC Control Module																																																									
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																									
C	2010	Silverado Hybrid	Body	Park Assist Module																																																									
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																									
C	2010	Silverado Hybrid	Body	Passenger Presence System																																																									
C	2010	Silverado Hybrid	Body	Radio																																																									
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																									
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																									
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																									
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																									
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																									
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2010	Tahoe	Chassis	Electronic Brake Control Module																																																									
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																									
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Tahoe	Body	Amplifier (Bose)																																																									
C	2010	Tahoe	Body	Assist Step Controller																																																									
C	2010	Tahoe	Body	Body Control Module																																																									
C	2010	Tahoe	Body	Body Control Module (aux.)																																																									
C	2010	Tahoe	Body	Digital Radio Receiver																																																									
C	2010	Tahoe	Body	Driver Door Switch																																																									
C	2010	Tahoe	Body	HVAC Control Module Auto									V																																															
C	2010	Tahoe	Body	HVAC Control Module Manual																																																									
C	2010	Tahoe	Body	Instrument Panel Cluster																																																									
C	2010	Tahoe	Body	Left Side Object Detection Module																																																									
C	2010	Tahoe	Body	Lift Gate Module																																																									
C	2010	Tahoe	Body	Memory Seat Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2010	Tahoe	Body	Park Assist Module																																																								
C	2010	Tahoe	Body	Passenger Door Switch																																																								
C	2010	Tahoe	Body	Passenger Presence System																																																								
C	2010	Tahoe	Body	Radio																																																								
C	2010	Tahoe	Body	Rear Heated Seat Module																																																								
C	2010	Tahoe	Body	Rear HVAC/RSA																																																								
C	2010	Tahoe	Body	Right Side Object Detection Module																																																								
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																								
C	2010	Tahoe	Body	Theft Deterrent Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
C	2010	Tahoe Hybrid	Body	Body Control Module																																																								
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																																								
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																																								
C	2010	Tahoe Hybrid	Body	HVAC Control Module																																																								
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																																								
C	2010	Tahoe Hybrid	Body	Park Assist Module																																																								
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																								
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																																								
C	2010	Tahoe Hybrid	Body	Radio																																																								
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2011	Avalanche	Chassis	Electronic Brake Control Module																																																								
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																								
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2011	Avalanche	Body	Amplifier (Bose)																																																								
C	2011	Avalanche	Body	Assist Step Controller																																																								
C	2011	Avalanche	Body	Body Control Module																																																								
C	2011	Avalanche	Body	Body Control Module (aux.)																																																								
C	2011	Avalanche	Body	Digital Radio Receiver																																																								
C	2011	Avalanche	Body	Driver Door Switch																																																								
C	2011	Avalanche	Body	HVAC Control Module Auto									V																																															
C	2011	Avalanche	Body	HVAC Control Module Manual																																																									
C	2011	Avalanche	Body	Instrument Panel Cluster																																																									
C	2011	Avalanche	Body	Memory Seat Module																																																									
C	2011	Avalanche	Body	Park Assist Module																																																									
C	2011	Avalanche	Body	Passenger Door Switch																																																									
C	2011	Avalanche	Body	Passenger Presence System																																																									
C	2011	Avalanche	Body	Radio																																																									
C	2011	Avalanche	Body	Rear Heated Seat Module																																																									
C	2011	Avalanche	Body	Rear HVAC/RSA																																																									
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																									
C	2011	Avalanche	Body	Theft Deterrent Module																																																									
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																									
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																									
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																									
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																									
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																									
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																									
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																									
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																									
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																									
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																									
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																									
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																									
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																									
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																									
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																									
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																									
C	2011	Captiva	Chassis	Electronic Brake Control Module																																																									
C	2011	Captiva	Chassis	Parking Brake Control Module																																																									
C	2011	Captiva	Body	Body Control Module																																																									
C	2011	Captiva	Body	Auxiliary Body Control Module																																																									
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2011	Captiva	Body	Instrument Cluster																																																									
C	2011	Captiva	Body	Headlamp Control Module																																																									
C	2011	Captiva	Body	HVAC Control Module																																																									
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																									
C	2011	Captiva	Body	Parking Assist Control Module																																																									
C	2011	Captiva	Body	Theft Deterrent Module																																																									
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																								
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																								
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																								
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Cheyenne	Body	Amplifier (Bose)																																																								
C	2011	Cheyenne	Body	Body Control Module																																																								
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																								
C	2011	Cheyenne	Body	Digital Radio Receiver																																																								
C	2011	Cheyenne	Body	Driver Door Switch																																																								
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																								
C	2011	Cheyenne	Body	Park Assist Module																																																								
C	2011	Cheyenne	Body	Passenger Door Switch																																																								
C	2011	Cheyenne	Body	Passenger Presence System																																																								
C	2011	Cheyenne	Body	Rear Heated Seat Module																																																								
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																								
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																								
C	2011	Cheyenne	Body	Theft Deterrent Module																																																								
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																								
C	2011	Suburban	Chassis	Electronic Suspension Control																																																								
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Suburban	Body	Amplifier (Bose)																																																								
C	2011	Suburban	Body	Assist Step Controller																																																								
C	2011	Suburban	Body	Body Control Module																																																								
C	2011	Suburban	Body	Body Control Module (aux.)																																																								
C	2011	Suburban	Body	Digital Radio Receiver																																																								
C	2011	Suburban	Body	Driver Door Switch																																																								
C	2011	Suburban	Body	HVAC Control Module Auto									V																																														
C	2011	Suburban	Body	HVAC Control Module Manual																																																								
C	2011	Suburban	Body	Instrument Panel Cluster																																																								
C	2011	Suburban	Body	Left Side Object Detection Module																																																								
C	2011	Suburban	Body	Lift Gate Module																																																								
C	2011	Suburban	Body	Memory Seat Module																																																								
C	2011	Suburban	Body	Park Assist Module																																																								
C	2011	Suburban	Body	Passenger Door Switch																																																								
C	2011	Suburban	Body	Passenger Presence System																																																								
C	2011	Suburban	Body	Radio																																																								
C	2011	Suburban	Body	Rear Heated Seat Module																																																								
C	2011	Suburban	Body	Rear HVAC/RSA																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2011	Suburban	Body	Right Side Object Detection Module																																																									
C	2011	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2011	Suburban	Body	Theft Deterrent Module																																																										
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																						V																			
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																						V																			
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																										
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module											V																																														
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																														
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2011	Silverado	Chassis	Electronic Suspension Control																																																										
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2011	Silverado	Body	Amplifier (Bose)																																																										
C	2011	Silverado	Body	Body Control Module																																																									
C	2011	Silverado	Body	Body Control Module (aux.)																																																										
C	2011	Silverado	Body	Digital Radio Receiver																																																										
C	2011	Silverado	Body	Driver Door Switch																																																										
C	2011	Silverado	Body	HVAC Control Module Auto									V																																																
C	2011	Silverado	Body	HVAC Control Module Manual									V																																																
C	2011	Silverado	Body	Instrument Panel Cluster																																																										
C	2011	Silverado	Body	Memory Seat Module																																																										
C	2011	Silverado	Body	Park Assist Module																																																										
C	2011	Silverado	Body	Passenger Door Switch																																																										
C	2011	Silverado	Body	Passenger Presence System																																																										
C	2011	Silverado	Body	Radio																																																										
C	2011	Silverado	Body	Rear Heated Seat Module																																																										
C	2011	Silverado	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																																								
C	2011	Silverado	Body	Theft Deterrent Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																								
C	2011	Silverado Hybrid	Body	Body Control Module																																																								
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																								
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																								
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																								
C	2011	Silverado Hybrid	Body	HVAC Control Module																																																								
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
C	2011	Silverado Hybrid	Body	Park Assist Module																																																								
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																								
C	2011	Silverado Hybrid	Body	Passenger Presence System																																																								
C	2011	Silverado Hybrid	Body	Radio																																																								
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																								
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2011	Tahoe	Chassis	Electronic Brake Control Module																																																								
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																								
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Tahoe	Body	Amplifier (Bose)																																																								
C	2011	Tahoe	Body	Assist Step Controller																																																								
C	2011	Tahoe	Body	Body Control Module																																																								
C	2011	Tahoe	Body	Body Control Module (aux.)																																																								
C	2011	Tahoe	Body	Digital Radio Receiver																																																								
C	2011	Tahoe	Body	Driver Door Switch																																																								
C	2011	Tahoe	Body	HVAC Control Module Auto									V																																															
C	2011	Tahoe	Body	HVAC Control Module Manual																																																								
C	2011	Tahoe	Body	Instrument Panel Cluster																																																								
C	2011	Tahoe	Body	Left Side Object Detection Module																																																								
C	2011	Tahoe	Body	Lift Gate Module																																																								
C	2011	Tahoe	Body	Memory Seat Module																																																								
C	2011	Tahoe	Body	Park Assist Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2011	Tahoe	Body	Passenger Door Switch																																																								
C	2011	Tahoe	Body	Passenger Presence System																																																								
C	2011	Tahoe	Body	Radio																																																								
C	2011	Tahoe	Body	Rear Heated Seat Module																																																								
C	2011	Tahoe	Body	Rear HVAC/RSA																																																								
C	2011	Tahoe	Body	Right Side Object Detection Module																																																								
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																								
C	2011	Tahoe	Body	Theft Deterrent Module																																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
C	2011	Tahoe Hybrid	Body	Body Control Module																																																								
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																																								
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																																								
C	2011	Tahoe Hybrid	Body	HVAC Control Module																																																								
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																																								
C	2011	Tahoe Hybrid	Body	Park Assist Module																																																								
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																								
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																																								
C	2011	Tahoe Hybrid	Body	Radio																																																								
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																														
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2012	Avalanche	Chassis	Electronic Brake Control Module																																																								
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																								
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2012	Avalanche	Body	Amplifier (Bose)																																																								
C	2012	Avalanche	Body	Assist Step Controller																																																								
C	2012	Avalanche	Body	Body Control Module																																																								
C	2012	Avalanche	Body	Body Control Module (aux.)																																																								
C	2012	Avalanche	Body	Digital Radio Receiver																																																								
C	2012	Avalanche	Body	Driver Door Switch																																																								
C	2012	Avalanche	Body	HVAC Control Module Auto									V																																															
C	2012	Avalanche	Body	HVAC Control Module Manual																																																									
C	2012	Avalanche	Body	Instrument Panel Cluster																																																									
C	2012	Avalanche	Body	Memory Seat Module																																																									
C	2012	Avalanche	Body	Navigation Radio																																																									
C	2012	Avalanche	Body	Park Assist Module																																																									
C	2012	Avalanche	Body	Passenger Door Switch																																																									
C	2012	Avalanche	Body	Passenger Presence System																																																									
C	2012	Avalanche	Body	Radio																																																									
C	2012	Avalanche	Body	Rear Heated Seat Module																																																									
C	2012	Avalanche	Body	Rear HVAC/RSA																																																									
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																									
C	2012	Avalanche	Body	Theft Deterrent Module																																																									
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																									
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																									
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																									
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																									
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																									
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																									
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																									
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																									
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																									
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																									
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																									
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																									
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																									
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																									
C	2012	Captiva	Chassis	Parking Brake Control Module																																																									
C	2012	Captiva	Body	Body Control Module																																																									
C	2012	Captiva	Body	Auxiliary Body Control Module																																																									
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2012	Captiva	Body	Instrument Cluster																																																									
C	2012	Captiva	Body	Headlamp Control Module																																																									
C	2012	Captiva	Body	HVAC Control Module																																																									
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																									
C	2012	Captiva	Body	Parking Assist Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2012	Captiva	Body	Theft Deterrent Module																																																								
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																						V																		
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																						V																		
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																														
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																									
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																									
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																									
C	2012	Cheyenne	Body	Amplifier (Bose)																																																									
C	2012	Cheyenne	Body	Body Control Module																																																									
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																									
C	2012	Cheyenne	Body	Digital Radio Receiver																																																									
C	2012	Cheyenne	Body	Driver Door Switch																																																									
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																									
C	2012	Cheyenne	Body	Park Assist Module																																																									
C	2012	Cheyenne	Body	Passenger Door Switch																																																									
C	2012	Cheyenne	Body	Passenger Presence System																																																									
C	2012	Cheyenne	Body	Rear Heated Seat Module																																																									
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																									
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																									
C	2012	Cheyenne	Body	Theft Deterrent Module																																																									
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																														
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																									
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
C	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																									
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2012	Suburban	Chassis	Electronic Suspension Control																																																									
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2012	Suburban	Body	Amplifier (Bose)																																																									
C	2012	Suburban	Body	Assist Step Controller																																																									
C	2012	Suburban	Body	Body Control Module																																																									
C	2012	Suburban	Body	Body Control Module (aux.)																																																									
C	2012	Suburban	Body	Digital Radio Receiver																																																									
C	2012	Suburban	Body	Driver Door Switch																																																									
C	2012	Suburban	Body	HVAC Control Module Auto									V																																															
C	2012	Suburban	Body	HVAC Control Module Manual																																																									
C	2012	Suburban	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2012	Suburban	Body	Left Side Object Detection Module																																																								
C	2012	Suburban	Body	Lift Gate Module																																																								
C	2012	Suburban	Body	Memory Seat Module																																																								
C	2012	Suburban	Body	Navigation Radio																																																								
C	2012	Suburban	Body	Park Assist Module																																																								
C	2012	Suburban	Body	Passenger Door Switch																																																								
C	2012	Suburban	Body	Passenger Presence System																																																								
C	2012	Suburban	Body	Radio																																																								
C	2012	Suburban	Body	Rear Heated Seat Module																																																								
C	2012	Suburban	Body	Rear HVAC/RSA																																																								
C	2012	Suburban	Body	Right Side Object Detection Module																																																								
C	2012	Suburban	Body	Supplemental Inflatable Restraint																																																								
C	2012	Suburban	Body	Theft Deterrent Module																																																								
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																						V																		
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																						V																		
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																													
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																													
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																								
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																								
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module											V																																												
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																												
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																								
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
C	2012	Silverado	Chassis	Electronic Suspension Control																																																								
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
C	2012	Silverado	Body	Amplifier (Bose)																																																								
C	2012	Silverado	Body	Body Control Module																																																								
C	2012	Silverado	Body	Body Control Module (aux.)																																																								
C	2012	Silverado	Body	Digital Radio Receiver																																																								
C	2012	Silverado	Body	Driver Door Switch																																																								
C	2012	Silverado	Body	HVAC Control Module Auto										V																																														

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2012	Silverado	Body	HVAC Control Module Manual									V																																															
C	2012	Silverado	Body	Instrument Panel Cluster																																																								
C	2012	Silverado	Body	Memory Seat Module																																																								
C	2012	Silverado	Body	Navigation Radio																																																								
C	2012	Silverado	Body	Park Assist Module																																																								
C	2012	Silverado	Body	Passenger Door Switch																																																								
C	2012	Silverado	Body	Passenger Presence System																																																								
C	2012	Silverado	Body	Radio																																																								
C	2012	Silverado	Body	Rear Heated Seat Module																																																								
C	2012	Silverado	Body	Rear HVAC/RSA																																																								
C	2012	Silverado	Body	Supplemental Inflatable Restraint																																																								
C	2012	Silverado	Body	Theft Deterrent Module																																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																								
C	2012	Silverado Hybrid	Body	Body Control Module																																																								
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																								
C	2012	Silverado Hybrid	Body	Driver Door Switch																																																								
C	2012	Silverado Hybrid	Body	Heated Seat Module																																																								
C	2012	Silverado Hybrid	Body	HVAC Control Module																																																								
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
C	2012	Silverado Hybrid	Body	Navigation Radio																																																								
C	2012	Silverado Hybrid	Body	Park Assist Module																																																								
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																																								
C	2012	Silverado Hybrid	Body	Passenger Presence System																																																								
C	2012	Silverado Hybrid	Body	Radio																																																								
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																								
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2012	Tahoe	Chassis	Electronic Brake Control Module																																																								
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																								
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
C	2012	Tahoe	Body	Amplifier (Bose)																																																								
C	2012	Tahoe	Body	Assist Step Controller																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2012	Tahoe	Body	Body Control Module																																																								
C	2012	Tahoe	Body	Body Control Module (aux.)																																																								
C	2012	Tahoe	Body	Digital Radio Receiver																																																								
C	2012	Tahoe	Body	Driver Door Switch																																																								
C	2012	Tahoe	Body	HVAC Control Module Auto									V																																															
C	2012	Tahoe	Body	HVAC Control Module Manual																																																								
C	2012	Tahoe	Body	Instrument Panel Cluster																																																								
C	2012	Tahoe	Body	Left Side Object Detection Module																																																								
C	2012	Tahoe	Body	Lift Gate Module																																																								
C	2012	Tahoe	Body	Memory Seat Module																																																								
C	2012	Tahoe	Body	Navigation Radio																																																								
C	2012	Tahoe	Body	Park Assist Module																																																								
C	2012	Tahoe	Body	Passenger Door Switch																																																								
C	2012	Tahoe	Body	Passenger Presence System																																																								
C	2012	Tahoe	Body	Radio																																																								
C	2012	Tahoe	Body	Rear Heated Seat Module																																																								
C	2012	Tahoe	Body	Rear HVAC/RSA																																																								
C	2012	Tahoe	Body	Right Side Object Detection Module																																																								
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																								
C	2012	Tahoe	Body	Theft Deterrent Module																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
C	2012	Tahoe Hybrid	Body	Body Control Module																																																								
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																																								
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																																								
C	2012	Tahoe Hybrid	Body	HVAC Control Module																																																								
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
C	2012	Tahoe Hybrid	Body	Lift Gate Module																																																								
C	2012	Tahoe Hybrid	Body	Navigation Radio																																																								
C	2012	Tahoe Hybrid	Body	Park Assist Module																																																								
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																								
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																																								
C	2012	Tahoe Hybrid	Body	Radio																																																								
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																														
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2013	Avalanche	Chassis	Electronic Brake Control Module																																																									
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																									
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Avalanche	Body	Amplifier (Bose)																																																									
C	2013	Avalanche	Body	Assist Step Controller																																																									
C	2013	Avalanche	Body	Body Control Module																																																									
C	2013	Avalanche	Body	Body Control Module (aux.)																																																									
C	2013	Avalanche	Body	Digital Radio Receiver																																																									
C	2013	Avalanche	Body	Driver Door Switch																																																									
C	2013	Avalanche	Body	HVAC Control Module Auto									V																																															
C	2013	Avalanche	Body	HVAC Control Module Manual																																																									
C	2013	Avalanche	Body	Instrument Panel Cluster																																																									
C	2013	Avalanche	Body	Memory Seat Module																																																									
C	2013	Avalanche	Body	Navigation Radio																																																									
C	2013	Avalanche	Body	Park Assist Module																																																									
C	2013	Avalanche	Body	Passenger Door Switch																																																									
C	2013	Avalanche	Body	Passenger Presence System																																																									
C	2013	Avalanche	Body	Radio																																																									
C	2013	Avalanche	Body	Rear Heated Seat Module																																																									
C	2013	Avalanche	Body	Rear HVAC/RSA																																																									
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																									
C	2013	Avalanche	Body	Theft Deterrent Module																																																									
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																									
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																									
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																									
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																									
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																									
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																									
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																									
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																									
C	2013	Captiva	Chassis	Electronic Brake Control Module																																																									
C	2013	Captiva	Chassis	Parking Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																								
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																								
C	2013	Captiva	Body	Auxiliary Body Control Module																																																								
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2013	Captiva	Body	Instrument Cluster																																																								
C	2013	Captiva	Body	Headlamp Control Module																																																								
C	2013	Captiva	Body	HVAC Control Module																																																								
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																								
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																								
C	2013	Captiva	Body	Theft Deterrent Module																																																								
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																						V																		
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																						V																		
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																														
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																								
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																								
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Cheyenne	Body	Amplifier (Bose)																																																								
C	2013	Cheyenne	Body	Body Control Module																																																								
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																								
C	2013	Cheyenne	Body	Digital Radio Receiver																																																								
C	2013	Cheyenne	Body	Driver Door Switch																																																								
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																								
C	2013	Cheyenne	Body	Park Assist Module																																																								
C	2013	Cheyenne	Body	Passenger Door Switch																																																								
C	2013	Cheyenne	Body	Passenger Presence System																																																								
C	2013	Cheyenne	Body	Rear Heated Seat Module																																																								
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																								
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																								
C	2013	Cheyenne	Body	Theft Deterrent Module																																																								
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																														
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																								
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
C	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																								
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2013	Suburban	Chassis	Electronic Suspension Control																																																								
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																								
C	2013	Suburban	Body	Amplifier (Bose)																																																								
C	2013	Suburban	Body	Assist Step Controller																																																								
C	2013	Suburban	Body	Body Control Module																																																								
C	2013	Suburban	Body	Body Control Module (aux.)																																																								
C	2013	Suburban	Body	Digital Radio Receiver																																																								
C	2013	Suburban	Body	Driver Door Switch																																																								
C	2013	Suburban	Body	HVAC Control Module Auto									V																																															
C	2013	Suburban	Body	HVAC Control Module Manual																																																								
C	2013	Suburban	Body	Instrument Panel Cluster																																																								
C	2013	Suburban	Body	Left Side Object Detection Module																																																								
C	2013	Suburban	Body	Lift Gate Module																																																								
C	2013	Suburban	Body	Memory Seat Module																																																								
C	2013	Suburban	Body	Navigation Radio																																																								
C	2013	Suburban	Body	Park Assist Module																																																								
C	2013	Suburban	Body	Passenger Door Switch																																																								
C	2013	Suburban	Body	Passenger Presence System																																																								
C	2013	Suburban	Body	Radio																																																								
C	2013	Suburban	Body	Rear Heated Seat Module																																																								
C	2013	Suburban	Body	Rear HVAC/RSA																																																								
C	2013	Suburban	Body	Right Side Object Detection Module																																																								
C	2013	Suburban	Body	Supplemental Inflatable Restraint																																																								
C	2013	Suburban	Body	Theft Deterrent Module																																																								
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																					V																			
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																					V																			
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																														
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																								
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																								
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																								
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module											V																																													
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
C	2013	Silverado	Chassis	Electronic Suspension Control																																																										
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
C	2013	Silverado	Body	Amplifier (Bose)																																																										
C	2013	Silverado	Body	Body Control Module																																																										
C	2013	Silverado	Body	Body Control Module (aux.)																																																										
C	2013	Silverado	Body	Digital Radio Receiver																																																										
C	2013	Silverado	Body	Driver Door Switch																																																										
C	2013	Silverado	Body	HVAC Control Module Auto									V																																																
C	2013	Silverado	Body	HVAC Control Module Manual									V																																																
C	2013	Silverado	Body	Instrument Panel Cluster																																																										
C	2013	Silverado	Body	Memory Seat Module																																																										
C	2013	Silverado	Body	Navigation Radio																																																										
C	2013	Silverado	Body	Park Assist Module																																																										
C	2013	Silverado	Body	Passenger Door Switch																																																										
C	2013	Silverado	Body	Passenger Presence System																																																										
C	2013	Silverado	Body	Radio																																																										
C	2013	Silverado	Body	Rear Heated Seat Module																																																										
C	2013	Silverado	Body	Rear HVAC/RSA																																																										
C	2013	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2013	Silverado	Body	Theft Deterrent Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																					
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2013	Silverado Hybrid	Body	Body Control Module																																																										
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2013	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2013	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2013	Silverado Hybrid	Body	HVAC Control Module																																																										
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2013	Silverado Hybrid	Body	Navigation Radio																																																										
C	2013	Silverado Hybrid	Body	Park Assist Module																																																										
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2013	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2013	Silverado Hybrid	Body	Radio																																																										
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																									
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																									
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																									
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2013	Tahoe	Chassis	Electronic Brake Control Module																																																									
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																									
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Tahoe	Body	Amplifier (Bose)																																																									
C	2013	Tahoe	Body	Assist Step Controller																																																									
C	2013	Tahoe	Body	Body Control Module																																																									
C	2013	Tahoe	Body	Body Control Module (aux.)																																																									
C	2013	Tahoe	Body	Digital Radio Receiver																																																									
C	2013	Tahoe	Body	Driver Door Switch																																																									
C	2013	Tahoe	Body	HVAC Control Module Auto									V																																																
C	2013	Tahoe	Body	HVAC Control Module Manual																																																									
C	2013	Tahoe	Body	Instrument Panel Cluster																																																									
C	2013	Tahoe	Body	Left Side Object Detection Module																																																									
C	2013	Tahoe	Body	Lift Gate Module																																																									
C	2013	Tahoe	Body	Memory Seat Module																																																									
C	2013	Tahoe	Body	Navigation Radio																																																									
C	2013	Tahoe	Body	Park Assist Module																																																									
C	2013	Tahoe	Body	Passenger Door Switch																																																									
C	2013	Tahoe	Body	Passenger Presence System																																																									
C	2013	Tahoe	Body	Radio																																																									
C	2013	Tahoe	Body	Rear Heated Seat Module																																																									
C	2013	Tahoe	Body	Rear HVAC/RSA																																																									
C	2013	Tahoe	Body	Right Side Object Detection Module																																																									
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																									
C	2013	Tahoe	Body	Theft Deterrent Module																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																				
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
C	2013	Tahoe Hybrid	Body	Body Control Module																																																									
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																																									
C	2013	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2013	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2013	Tahoe Hybrid	Body	Navigation Radio																																																										
C	2013	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2013	Tahoe Hybrid	Body	Radio																																																										
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
C	2014	Captiva (3GN)	Body	Body Control Module																																																										
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Captiva (3GN)	Body	Passenger Presence Module																																																										
C	2014	Captiva (3GN)	Body	Instrument Cluster																																																										
C	2014	Captiva (3GN)	Body	Radio																																																										
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Captiva (3GN)	Body	HVAC Control Module																																																										
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																										
C	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																								
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																								
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																								
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																								
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																								
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																								
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																								
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Captiva (Other)	Body	Instrument Cluster																																																								
C	2014	Captiva (Other)	Body	Headlamp Control Module																																																								
C	2014	Captiva (Other)	Body	HVAC Control Module																																																								
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																								
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																								
C	2014	Captiva (Other)	Body	Theft Deterrent Module																																																								
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																								
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																								
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																								
C	2014	Cheyenne	Chassis	Power Steering Control Module																																																								
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2014	Cheyenne	Body	Body Control Module																																																								
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Cheyenne	Body	Passenger Presence Module																																																								
C	2014	Cheyenne	Body	Instrument Cluster																																																								
C	2014	Cheyenne	Body	Radio Control																																																								
C	2014	Cheyenne	Body	HVAC Control																																																								
C	2014	Cheyenne	Body	Radio																																																								
C	2014	Cheyenne	Body	Amplifier																																																								
C	2014	Cheyenne	Body	Media Disc Player																																																								
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																								
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																								
C	2014	Cheyenne	Body	HVAC Control Module																																																								
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																								
C	2014	Cheyenne	Body	Parking Assist Control Module																																																								
C	2014	Cheyenne	Body	Frontview Camera Module																																																								
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																								
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																								
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2014	Silverado	Chassis	Electronic Brake Control Module																																																								
C	2014	Silverado	Chassis	Parking Brake Control Module																																																								
C	2014	Silverado	Chassis	Power Steering Control Module																																																								
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2014	Silverado	Body	Body Control Module																																																								
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Silverado	Body	Passenger Presence Module																																																								
C	2014	Silverado	Body	Instrument Cluster																																																								
C	2014	Silverado	Body	Radio Control																																																								
C	2014	Silverado	Body	HVAC Control																																																								
C	2014	Silverado	Body	Radio																																																								
C	2014	Silverado	Body	Amplifier																																																								
C	2014	Silverado	Body	Media Disc Player																																																								
C	2014	Silverado	Body	Human Machine Interface Control Module																																																								
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																								
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																								
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																								
C	2014	Silverado	Body	Parking Assist Control Module																																																								
C	2014	Silverado	Body	Frontview Camera Module																																																								
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																								
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																								
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																								
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																								
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																								
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																								
C	2014	Silverado HD	Chassis	Suspension Control Module																																																								
C	2014	Silverado HD	Body	Body Control Module																																																								
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Silverado HD	Body	Passenger Presence Module																																																								
C	2014	Silverado HD	Body	Instrument Cluster																																																								
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																								
C	2014	Silverado HD	Body	Base Radio																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2014	Silverado HD	Body	Navigation Radio																																																								
C	2014	Silverado HD	Body	Uplevel Radio																																																								
C	2014	Silverado HD	Body	Amplifier																																																								
C	2014	Silverado HD	Body	Rear Audio Control Module																																																								
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																								
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																V								
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																								
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																								
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																								
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																								
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																								
C	2014	Silverado HD	Body	Seat Memory Control Module																																																								
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																								
C	2014	Silverado HD	Body	Parking Assist Control Module																																																								
C	2014	Silverado HD	Body	Theft Deterrent Module																																																								
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																								
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																								
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																								
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																								
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																								
C	2014	Suburban	Chassis	Parking Brake Control Module																																																								
C	2014	Suburban	Chassis	Suspension Control Module																																																								
C	2014	Suburban	Body	Body Control Module																																																								
C	2014	Suburban	Body	Auxiliary Body Control Module																																																								
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	Suburban	Body	Passenger Presence Module																																																								
C	2014	Suburban	Body	Instrument Cluster																																																								
C	2014	Suburban	Body	Base Radio																																																								
C	2014	Suburban	Body	Navigation Radio																																																								
C	2014	Suburban	Body	Uplevel Radio																																																								
C	2014	Suburban	Body	Amplifier																																																								
C	2014	Suburban	Body	Rear Audio Control Module																																																								
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																								
C	2014	Suburban	Body	Personal Audio Link Control Module																																																V								
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																								
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																								
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																								
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																								
C	2014	Suburban	Body	Liftgate Control Module																																																								
C	2014	Suburban	Body	Seat Memory Control Module																																																								
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2014	Suburban	Body	Assist Step Control Module																																																								
C	2014	Suburban	Body	Right Side Object Detection Control Module																																																									
C	2014	Suburban	Body	Left Side Object Detection Control Module																																																									
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																									
C	2014	Suburban	Body	Parking Assist Control Module																																																									
C	2014	Suburban	Body	Theft Deterrent Module																																																									
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																									
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																									
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																									
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																									
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																									
C	2014	Tahoe	Chassis	Suspension Control Module																																																									
C	2014	Tahoe	Body	Body Control Module																																																									
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																									
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2014	Tahoe	Body	Passenger Presence Module																																																									
C	2014	Tahoe	Body	Instrument Cluster																																																									
C	2014	Tahoe	Body	Base Radio																																																									
C	2014	Tahoe	Body	Navigation Radio																																																									
C	2014	Tahoe	Body	Uplevel Radio																																																									
C	2014	Tahoe	Body	Amplifier																																																									
C	2014	Tahoe	Body	Rear Audio Control Module																																																									
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																									
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																V									
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																									
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																									
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																									
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																									
C	2014	Tahoe	Body	Liftgate Control Module																																																									
C	2014	Tahoe	Body	Seat Memory Control Module																																																									
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																																									
C	2014	Tahoe	Body	Assist Step Control Module																																																									
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																																									
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																																									
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																									
C	2014	Tahoe	Body	Parking Assist Control Module																																																									
C	2014	Tahoe	Body	Theft Deterrent Module																																																									
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																									
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																									
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2015	Captiva (3GN)	Body	Body Control Module																																																								
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																																								
C	2015	Captiva (3GN)	Body	Instrument Cluster																																																								
C	2015	Captiva (3GN)	Body	Radio																																																								
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																								
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																								
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																								
C	2015	Captiva (3GN)	Body	HVAC Control Module																																																								
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																								
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																								
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																								
C	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																								
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																								
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																								
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																								
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																								
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																								
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																								
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																								
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																								
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																								
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																								
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2015	Captiva (Other)	Body	Instrument Cluster																																																								
C	2015	Captiva (Other)	Body	Headlamp Control Module																																																								
C	2015	Captiva (Other)	Body	HVAC Control Module																																																								
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																								
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																								
C	2015	Captiva (Other)	Body	Theft Deterrent Module																																																								
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																								
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																									
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																										
C	2015	Cheyenne	Chassis	Power Steering Control Module																																																										
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Cheyenne	Chassis	Suspension Control Module																																																										
C	2015	Cheyenne	Body	Body Control Module																																																										
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Cheyenne	Body	Passenger Presence Module																																																										
C	2015	Cheyenne	Body	Instrument Cluster																																																										
C	2015	Cheyenne	Body	Radio Controls																																																										
C	2015	Cheyenne	Body	HVAC Controls																																																										
C	2015	Cheyenne	Body	Radio																																																										
C	2015	Cheyenne	Body	Amplifier																																																										
C	2015	Cheyenne	Body	Media Disc Player																																																										
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																										
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
C	2015	Cheyenne	Body	HVAC Control Module																																																										
C	2015	Cheyenne	Body	Parking Assist Control Module																																																										
C	2015	Cheyenne	Body	Frontview Camera Module																																																										
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2015	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Silverado	Chassis	Power Steering Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2015	Silverado	Chassis	Suspension Control Module																																																										
C	2015	Silverado	Body	Body Control Module																																																										
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Silverado	Body	Passenger Presence Module																																																										
C	2015	Silverado	Body	Instrument Cluster																																																										
C	2015	Silverado	Body	Radio Controls																																																										
C	2015	Silverado	Body	HVAC Controls																																																										
C	2015	Silverado	Body	Radio																																																										
C	2015	Silverado	Body	Amplifier																																																										
C	2015	Silverado	Body	Media Disc Player																																																										
C	2015	Silverado	Body	Human Machine Interface Control Module																																																											
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																											
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
C	2015	Silverado	Body	Parking Assist Control Module																																																											
C	2015	Silverado	Body	Frontview Camera Module																																																											
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																											
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2015	Suburban	Chassis	Electronic Brake Control Module																																																											
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																											
C	2015	Suburban	Chassis	Parking Brake Control Module																																																											
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2015	Suburban	Chassis	Power Steering Control Module																																																											
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Suburban	Chassis	Suspension Control Module																																																											
C	2015	Suburban	Body	Body Control Module																																																											
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Suburban	Body	Passenger Presence Module																																																											
C	2015	Suburban	Body	Instrument Cluster																																																											
C	2015	Suburban	Body	Radio Controls																																																										
C	2015	Suburban	Body	HVAC Controls																																																										
C	2015	Suburban	Body	Radio																																																										
C	2015	Suburban	Body	Amplifier																																																										
C	2015	Suburban	Body	Media Disc Player																																																										
C	2015	Suburban	Body	Human Machine Interface Control Module																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2015	Suburban	Body	HVAC Control Module																																																											
C	2015	Suburban	Body	Liftgate Control Module																																																											
C	2015	Suburban	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2015	Suburban	Body	Assist Step Control Module																																																								
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																									
C	2015	Suburban	Body	Parking Assist Control Module																																																									
C	2015	Suburban	Body	Frontview Camera Module																																																									
C	2015	Suburban	Body	Steering Column Lock Control Module																																																									
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																									
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																									
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																									
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																									
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																									
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																																									
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																									
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																									
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																									
C	2015	Tahoe	Chassis	Power Steering Control Module																																																									
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2015	Tahoe	Chassis	Suspension Control Module																																																									
C	2015	Tahoe	Body	Body Control Module																																																									
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2015	Tahoe	Body	Passenger Presence Module																																																									
C	2015	Tahoe	Body	Instrument Cluster																																																									
C	2015	Tahoe	Body	Radio Controls																																																									
C	2015	Tahoe	Body	HVAC Controls																																																									
C	2015	Tahoe	Body	Radio																																																									
C	2015	Tahoe	Body	Amplifier																																																									
C	2015	Tahoe	Body	Media Disc Player																																																									
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																									
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																									
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																									
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																									
C	2015	Tahoe	Body	HVAC Control Module																																																									
C	2015	Tahoe	Body	Liftgate Control Module																																																									
C	2015	Tahoe	Body	Keyless Entry Control Module																																																									
C	2015	Tahoe	Body	Assist Step Control Module																																																									
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																									
C	2015	Tahoe	Body	Parking Assist Control Module																																																									
C	2015	Tahoe	Body	Frontview Camera Module																																																									
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																									
C	2015	Tahoe	Body	Battery Energy Control Module																																																									
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																									
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																									
C	2016	Captiva (3GN)	Body	Body Control Module																																																									
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																									
C	2016	Captiva (3GN)	Body	Radio																																																									
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																									
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																									
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																									
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																									
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																									
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																									
C	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																									
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																									
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																									
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																									
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																									
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																									
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																									
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																									
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																									
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																									
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																									
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																									
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																									
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Captiva (Other)	Body	Instrument Cluster																																																									
C	2016	Captiva (Other)	Body	Headlamp Control Module																																																									
C	2016	Captiva (Other)	Body	Radio																																																									
C	2016	Captiva (Other)	Body	HVAC Control Module																																																									
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																									
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																									
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																									
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																									
C	2016	Captiva (Other)	Body	Theft Deterrent Module																																																									
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																								
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																								
C	2016	Cheyenne	Chassis	Power Steering Control Module																																																								
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2016	Cheyenne	Chassis	Suspension Control Module																																																								
C	2016	Cheyenne	Body	Body Control Module																																																								
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2016	Cheyenne	Body	Passenger Presence Module																																																								
C	2016	Cheyenne	Body	Instrument Cluster																																																								
C	2016	Cheyenne	Body	Radio Controls																																																								
C	2016	Cheyenne	Body	HVAC Controls																																																								
C	2016	Cheyenne	Body	Radio																																																								
C	2016	Cheyenne	Body	Amplifier																																																								
C	2016	Cheyenne	Body	Media Disc Player																																																								
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																								
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																								
C	2016	Cheyenne	Body	HVAC Control Module																																																								
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																								
C	2016	Cheyenne	Body	Parking Assist Control Module																																																								
C	2016	Cheyenne	Body	Frontview Camera Module																																																								
C	2016	Cheyenne	Body	Frontview Camera Module																																																								
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																								
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																								
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																								
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																								
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																								
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																								
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																								
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																								
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																								
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
C	2016	Silverado	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2016	Silverado	Chassis	Power Steering Control Module																																																									
C	2016	Silverado	Chassis	Power Steering Control Module																																																										
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Silverado	Chassis	Suspension Control Module																																																										
C	2016	Silverado	Body	Body Control Module																																																										
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Silverado	Body	Passenger Presence Module																																																										
C	2016	Silverado	Body	Instrument Cluster																																																										
C	2016	Silverado	Body	Radio Controls																																																										
C	2016	Silverado	Body	HVAC Controls																																																										
C	2016	Silverado	Body	Radio (IO3)																																																										
C	2016	Silverado	Body	Radio (IOB)																																																										
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
C	2016	Silverado	Body	Amplifier																																																										
C	2016	Silverado	Body	Media Disc Player																																																										
C	2016	Silverado	Body	Human Machine Interface Control Module																																																										
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																										
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																										
C	2016	Silverado	Body	Parking Assist Control Module																																																										
C	2016	Silverado	Body	Frontview Camera Module																																																										
C	2016	Silverado	Body	Frontview Camera Module																																																										
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
C	2016	Suburban	Chassis	Parking Brake Control Module																																																										
C	2016	Suburban	Chassis	Power Steering Control Module																																																										
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Suburban	Chassis	Suspension Control Module																																																										
C	2016	Suburban	Body	Body Control Module																																																										
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Suburban	Body	Passenger Presence Module																																																										
C	2016	Suburban	Body	Instrument Cluster																																																										
C	2016	Suburban	Body	Radio Controls																																																										
C	2016	Suburban	Body	HVAC Controls																																																										
C	2016	Suburban	Body	Radio																																																										
C	2016	Suburban	Body	Amplifier																																																										
C	2016	Suburban	Body	Media Disc Player																																																										
C	2016	Suburban	Body	Human Machine Interface Control Module																																																										
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																																										
C	2016	Suburban	Body	HVAC Control Module																																																										
C	2016	Suburban	Body	Liftgate Control Module																																																V									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																								
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																									
C	2016	Suburban	Body	Keyless Entry Control Module																																																									
C	2016	Suburban	Body	Assist Step Control Module																																																									
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																									
C	2016	Suburban	Body	Parking Assist Control Module																																																									
C	2016	Suburban	Body	Frontview Camera Module																																																									
C	2016	Suburban	Body	Steering Column Lock Control Module																																																									
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																																									
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																									
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																									
C	2016	Tahoe	Chassis	Power Steering Control Module																																																									
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																									
C	2016	Tahoe	Chassis	Suspension Control Module																																																									
C	2016	Tahoe	Body	Body Control Module																																																									
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Tahoe	Body	Passenger Presence Module																																																									
C	2016	Tahoe	Body	Instrument Cluster																																																									
C	2016	Tahoe	Body	Radio Controls																																																									
C	2016	Tahoe	Body	HVAC Controls																																																									
C	2016	Tahoe	Body	Radio																																																									
C	2016	Tahoe	Body	Amplifier																																																									
C	2016	Tahoe	Body	Media Disc Player																																																									
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																									
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																									
C	2016	Tahoe	Body	HVAC Control Module																																																									
C	2016	Tahoe	Body	Liftgate Control Module																																																	V									
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																									
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																									
C	2016	Tahoe	Body	Keyless Entry Control Module																																																									
C	2016	Tahoe	Body	Assist Step Control Module																																																									
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																									
C	2016	Tahoe	Body	Parking Assist Control Module																																																									
C	2016	Tahoe	Body	Frontview Camera Module																																																									
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																									
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																									
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																									
E	2004	ALL	Chassis	Electronic Brake Control Module																																																									
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																									
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																									
E	2006	ALL	Chassis	Electronic Brake Control Module																																																									
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																									
E	2007	ALL	Chassis	Electronic Brake Control Module																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																							
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																							
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																							
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																							
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																								
G	2004	Express/Savana	Chassis	VSES																																																							
G	2004	Express/Savana	Body	Body Control Module																																																							
G	2004	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																							
G	2004	Express/Savana	Body	OnStar																																																							
G	2004	Express/Savana	Body	Base Radio																																																							
G	2004	Express/Savana	Body	Uplevel Radio																																																							
G	2004	Express/Savana	Body	Remote Function Actuation																																																							
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																							
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																							
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																							
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																							
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																							
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																							
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																							
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																							
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																							
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																							
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																							
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																							
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																							
G	2004	Express Access/Savana Pro	Chassis	VSES																																																							
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																							
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																							
G	2004	Express Access/Savana Pro	Body	OnStar																																																							
G	2004	Express Access/Savana Pro	Body	Base Radio																																																							
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																							
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																							
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																							
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																							
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																							
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																							
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																							
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																							

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																				V																																					
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																				
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																							
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																				
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																							
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																							
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																							
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																							
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																								
G	2005	Express/Savana	Chassis	VSES																																																								
G	2005	Express/Savana	Body	Body Control Module																																																								
G	2005	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																	
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2005	Express/Savana	Body	Base Radio																																																								
G	2005	Express/Savana	Body	Uplevel Radio																																																								
G	2005	Express/Savana	Body	Remote Function Actuation																																																								
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																				V																																				
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																				
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																				
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
G	2005	Express Access/Savana Pro	Chassis	VSES																																																								
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																	
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
G	2005	Express Access/Savana Pro	Body	Base Radio																																																								
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																								
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																					
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																					
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2006	Express/Savana	Chassis	VSES																																																									
G	2006	Express/Savana	Body	Body Control Module																																																									
G	2006	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																		
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2006	Express/Savana	Body	Passenger Presence System																																																								V	
G	2006	Express/Savana	Body	Base Radio																																																									
G	2006	Express/Savana	Body	Uplevel Radio																																																										
G	2006	Express/Savana	Body	Remote Function Actuation																																																										
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																						
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																						
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																						
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2006	Express Access/Savana Pro	Chassis	VSES																																																									
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																		
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																								V	
G	2006	Express Access/Savana Pro	Body	Base Radio																																																										
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																							
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																							
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																							
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																							
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express/Savana	Body	Body Control Module																																																										
G	2007	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																		
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2007	Express/Savana	Body	Passenger Presence System																																																									V	
G	2007	Express/Savana	Body	Base Radio																																																										
G	2007	Express/Savana	Body	Uplevel Radio																																																										
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																						
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																						
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																							
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																							
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																							V	
G	2007	Express Access/Savana Pro	Body	Radio																																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																		
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module											V																																													
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																				V	V	V																																		
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																													
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module											V																																													
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2008	Express/Savana	Body	Body Control Module																																																								
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2008	Express/Savana	Body	Passenger Presence System																																																								
G	2008	Express/Savana	Body	Radio																																																								
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2008	Express/Savana	Body	Rollover Sensor																																																								
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2008	Express/Savana	Body	Theft Deterrent Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																		
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module											V																																													
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																				V	V	V																																		
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																													

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module											V																																														
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2008	Express Access/Savana Pro	Body	Radio																																																									
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2009	Express/Savana	Body	Body Control Module																																																									
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2009	Express/Savana	Body	Passenger Presence System																																																									
G	2009	Express/Savana	Body	Radio																																																									
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2009	Express/Savana	Body	Rollover Sensor																																																									
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2009	Express/Savana	Body	Theft Deterrent Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2009	Express Access/Savana Pro	Body	Radio																																																								
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																		
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2010	Express/Savana	Body	Body Control Module																																																								
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2010	Express/Savana	Body	Passenger Presence System																																																								
G	2010	Express/Savana	Body	Radio																																																								
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2010	Express/Savana	Body	Rollover Sensor																																																								
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2010	Express/Savana	Body	Theft Deterrent Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																		
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2010	Express Access/Savana Pro	Body	Radio																																																									
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																			
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2011	Express/Savana	Body	Body Control Module																																																									
G	2011	Express/Savana	Body	Digital Radio Receiver																																																									
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2011	Express/Savana	Body	Passenger Presence System																																																									
G	2011	Express/Savana	Body	Radio																																																								
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2011	Express/Savana	Body	Rollover Sensor																																																									
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2011	Express/Savana	Body	Theft Deterrent Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																			
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																														
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2011	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2011	Express Access/Savana Pro	Body	Radio																																																									
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																			
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																														
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2012	Express/Savana	Body	Body Control Module																																																									
G	2012	Express/Savana	Body	Digital Radio Receiver																																																									
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2012	Express/Savana	Body	Passenger Presence System																																																									
G	2012	Express/Savana	Body	Radio																																																									
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2012	Express/Savana	Body	Rollover Sensor																																																									
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2012	Express/Savana	Body	Theft Deterrent Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																			
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2012	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2012	Express Access/Savana Pro	Body	Radio																																																								
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																			
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2013	Express/Savana	Body	Body Control Module																																																								
G	2013	Express/Savana	Body	Digital Radio Receiver																																																								
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2013	Express/Savana	Body	Navigation Radio																																																								
G	2013	Express/Savana	Body	Park Assist Module																																																								
G	2013	Express/Savana	Body	Passenger Presence System																																																								
G	2013	Express/Savana	Body	Radio																																																								
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2013	Express/Savana	Body	Rollover Sensor																																																								
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2013	Express/Savana	Body	Theft Deterrent Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																			
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2013	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																								
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																								
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2013	Express Access/Savana Pro	Body	Radio																																																								
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																								
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																								
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																								
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																								
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																								
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																								
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																								
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2014	Express	Chassis	Electronic Brake Control Module																																																								
G	2014	Express	Body	Body Control Module																																																								
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
G	2014	Express	Body	Passenger Presence Module																																																								
G	2014	Express	Body	Rollover Sensor Module																																																								
G	2014	Express	Body	Instrument Cluster																																																								
G	2014	Express	Body	Chime Alarm Control Module																																																								
G	2014	Express	Body	Base Radio																																																								
G	2014	Express	Body	Navigation Radio																																																								
G	2014	Express	Body	Uplevel Radio																																																								
G	2014	Express	Body	Digital Radio Receiver Control Module																																																								
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																								
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																								
G	2014	Express	Body	Auxiliary Heater Control Module																																																								
G	2014	Express	Body	Remote Control Door Lock Receiver																																																								
G	2014	Express	Body	Parking Assist Control Module																																																								
G	2014	Express	Body	Theft Deterrent Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																								
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																								
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																								
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																								
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																								
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																								
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																								
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2014	Savana	Chassis	Electronic Brake Control Module																																																								
G	2014	Savana	Body	Body Control Module																																																								
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
G	2014	Savana	Body	Passenger Presence Module																																																								
G	2014	Savana	Body	Rollover Sensor Module																																																								
G	2014	Savana	Body	Instrument Cluster																																																								
G	2014	Savana	Body	Chime Alarm Control Module																																																								
G	2014	Savana	Body	Base Radio																																																								
G	2014	Savana	Body	Navigation Radio																																																								
G	2014	Savana	Body	Uplevel Radio																																																								
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																								
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																								
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																								
G	2014	Savana	Body	Auxiliary Heater Control Module																																																								
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																								
G	2014	Savana	Body	Parking Assist Control Module																																																								
G	2014	Savana	Body	Theft Deterrent Module																																																								
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2015	Express	Chassis	Electronic Brake Control Module																																																								
G	2015	Express	Body	Body Control Module																																																								
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
G	2015	Express	Body	Rollover Sensor Module																																																								
G	2015	Express	Body	Instrument Cluster																																																								
G	2015	Express	Body	Digital Radio Receiver Control Module																																																								
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																								
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																								
G	2015	Express	Body	Auxiliary Heater Control Module																																																								
G	2015	Express	Body	Remote Control Door Lock Receiver																																																								
G	2015	Express	Body	Parking Assist Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2015	Express	Body	Theft Deterrent Module																																																								
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
G	2015	Savana	Chassis	Electronic Brake Control Module																																																									
G	2015	Savana	Body	Body Control Module																																																								
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
G	2015	Savana	Body	Rollover Sensor Module																																																								
G	2015	Savana	Body	Instrument Cluster																																																								
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																								
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																								
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																								
G	2015	Savana	Body	Auxiliary Heater Control Module																																																								
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																								
G	2015	Savana	Body	Parking Assist Control Module																																																								
G	2015	Savana	Body	Theft Deterrent Module																																																								
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2016	Express	Chassis	Electronic Brake Control Module																																																								
G	2016	Express	Body	Body Control Module																																																								
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
G	2016	Express	Body	Instrument Cluster																																																								
G	2016	Express	Body	Chime Alarm Control Module																																																								
G	2016	Express	Body	Base Radio																																																								
G	2016	Express	Body	Navigation Radio																																																								
G	2016	Express	Body	Uplevel Radio																																																								
G	2016	Express	Body	Digital Radio Receiver Control Module																																																								
G	2016	Express	Body	Telematics Communication Interface Control Module																																																								
G	2016	Express	Body	Auxiliary Heater Control Module																																																								
G	2016	Express	Body	Remote Control Door Lock Receiver																																																								
G	2016	Express	Body	Parking Assist Control Module																																																								
G	2016	Express	Body	Theft Deterrent Module																																																								
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
G	2016	Savana	Chassis	Electronic Brake Control Module																																																								
G	2016	Savana	Body	Body Control Module																																																								
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
G	2016	Savana	Body	Instrument Cluster																																																								
G	2016	Savana	Body	Chime Alarm Control Module																																																								
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																								
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																								
G	2016	Savana	Body	Auxiliary Heater Control Module																																																								
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																								
G	2016	Savana	Body	Parking Assist Control Module																																																								
G	2016	Savana	Body	Theft Deterrent Module																																																								
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2004	Express/Savana	Chassis	VSES																																																								
H	2004	Express/Savana	Body	Body Control Module																																																								
H	2004	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2004	Express/Savana	Body	OnStar																																																								
H	2004	Express/Savana	Body	Base Radio																																																								
H	2004	Express/Savana	Body	Uplevel Radio																																																								
H	2004	Express/Savana	Body	Remote Function Actuation																																																								
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2004	Express Access/Savana Pro	Chassis	VSES																																																								
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2004	Express Access/Savana Pro	Body	OnStar																																																								
H	2004	Express Access/Savana Pro	Body	Base Radio																																																								
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																				
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																				
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2005	Express/Savana	Chassis	VSES																																																								
H	2005	Express/Savana	Body	Body Control Module																																																								
H	2005	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2005	Express/Savana	Body	Base Radio																																																								
H	2005	Express/Savana	Body	Uplevel Radio																																																								
H	2005	Express/Savana	Body	Remote Function Actuation																																																								
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																			V																																					
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																			V																																					
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2005	Express Access/Savana Pro	Chassis	VSES																																																								
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2005	Express Access/Savana Pro	Body	Base Radio																																																								
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																			V																																					
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																			V																																					
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2006	Express/Savana	Chassis	VSES																																																								
H	2006	Express/Savana	Body	Body Control Module																																																								
H	2006	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2006	Express/Savana	Body	Passenger Presence System																																																						V	
H	2006	Express/Savana	Body	Base Radio																																																								
H	2006	Express/Savana	Body	Uplevel Radio																																																								
H	2006	Express/Savana	Body	Remote Function Actuation																																																								
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																			V																																					
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																			V																																					
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2006	Express Access/Savana Pro	Chassis	VSES																																																								
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																						V	
H	2006	Express Access/Savana Pro	Body	Base Radio																																																								
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																			V																																					
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																			V																																					
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																			V																																					

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2007	Express/Savana	Body	Body Control Module																																																								
H	2007	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2007	Express/Savana	Body	Passenger Presence System																																																								V
H	2007	Express/Savana	Body	Base Radio																																																								
H	2007	Express/Savana	Body	Uplevel Radio																																																								
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																				
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																				
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																				
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																								V
H	2007	Express Access/Savana Pro	Body	Base Radio																																																								
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																		
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module											V																																													
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																				V	V	V																																		
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																													
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2008	Express/Savana	Body	Body Control Module																																																								
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2008	Express/Savana	Body	Passenger Presence System																																																								
H	2008	Express/Savana	Body	Radio																																																								
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2008	Express/Savana	Body	Rollover Sensor																																																								
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2008	Express/Savana	Body	Theft Deterrent Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																		
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module											V																																														
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																				V	V	V																																			
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																														
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2008	Express Access/Savana Pro	Body	Radio																																																									
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2009	Express/Savana	Body	Body Control Module																																																									
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2009	Express/Savana	Body	Passenger Presence System																																																									
H	2009	Express/Savana	Body	Radio																																																									
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2009	Express/Savana	Body	Rollover Sensor																																																									
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2009	Express/Savana	Body	Theft Deterrent Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2009	Express Access/Savana Pro	Body	Radio																																																									
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2010	Express/Savana	Body	Body Control Module																																																									
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2010	Express/Savana	Body	Passenger Presence System																																																									
H	2010	Express/Savana	Body	Radio																																																									
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2010	Express/Savana	Body	Rollover Sensor																																																									
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2010	Express/Savana	Body	Theft Deterrent Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2010	Express Access/Savana Pro	Body	Radio																																																									
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2011	Express/Savana	Body	Body Control Module																																																									
H	2011	Express/Savana	Body	Digital Radio Receiver																																																									
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2011	Express/Savana	Body	Passenger Presence System																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2011	Express/Savana	Body	Radio																																																								
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2011	Express/Savana	Body	Rollover Sensor																																																								
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2011	Express/Savana	Body	Theft Deterrent Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2011	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2011	Express Access/Savana Pro	Body	Radio																																																								
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2012	Express/Savana	Body	Body Control Module																																																								
H	2012	Express/Savana	Body	Digital Radio Receiver																																																								
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2012	Express/Savana	Body	Passenger Presence System																																																								
H	2012	Express/Savana	Body	Radio																																																								
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2012	Express/Savana	Body	Rollover Sensor																																																								
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2012	Express/Savana	Body	Theft Deterrent Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2012	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2012	Express Access/Savana Pro	Body	Radio																																																								
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2013	Express/Savana	Body	Body Control Module																																																								
H	2013	Express/Savana	Body	Digital Radio Receiver																																																								
H	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2013	Express/Savana	Body	Navigation Radio																																																								
H	2013	Express/Savana	Body	Park Assist Module																																																								
H	2013	Express/Savana	Body	Passenger Presence System																																																								
H	2013	Express/Savana	Body	Radio																																																								
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2013	Express/Savana	Body	Rollover Sensor																																																								
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2013	Express/Savana	Body	Theft Deterrent Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2013	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2013	Express Access/Savana Pro	Body	Navigation Radio																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																																									
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2013	Express Access/Savana Pro	Body	Radio																																																									
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																									
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																									
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																									
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																									
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																									
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																									
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																									
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2014	Express	Chassis	Electronic Brake Control Module																																																									
H	2014	Express	Body	Body Control Module																																																									
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
H	2014	Express	Body	Passenger Presence Module																																																									
H	2014	Express	Body	Rollover Sensor Module																																																									
H	2014	Express	Body	Instrument Cluster																																																									
H	2014	Express	Body	Chime Alarm Control Module																																																									
H	2014	Express	Body	Base Radio																																																									
H	2014	Express	Body	Navigation Radio																																																									
H	2014	Express	Body	Uplevel Radio																																																									
H	2014	Express	Body	Digital Radio Receiver Control Module																																																									
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																									
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																									
H	2014	Express	Body	Auxiliary Heater Control Module																																																									
H	2014	Express	Body	Remote Control Door Lock Receiver																																																									
H	2014	Express	Body	Parking Assist Control Module																																																									
H	2014	Express	Body	Theft Deterrent Module																																																									
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																									
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																									
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																									
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																									
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																									
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																									
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																									
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2014	Savana	Chassis	Electronic Brake Control Module																																																										
H	2014	Savana	Body	Body Control Module																																																									
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
H	2014	Savana	Body	Passenger Presence Module																																																									
H	2014	Savana	Body	Rollover Sensor Module																																																									
H	2014	Savana	Body	Instrument Cluster																																																									
H	2014	Savana	Body	Chime Alarm Control Module																																																									
H	2014	Savana	Body	Base Radio																																																									
H	2014	Savana	Body	Navigation Radio																																																									
H	2014	Savana	Body	Uplevel Radio																																																									
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																									
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																									
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																									
H	2014	Savana	Body	Auxiliary Heater Control Module																																																									
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																									
H	2014	Savana	Body	Parking Assist Control Module																																																									
H	2014	Savana	Body	Theft Deterrent Module																																																									
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2015	Express	Chassis	Electronic Brake Control Module																																																									
H	2015	Express	Body	Body Control Module																																																									
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
H	2015	Express	Body	Rollover Sensor Module																																																									
H	2015	Express	Body	Instrument Cluster																																																									
H	2015	Express	Body	Digital Radio Receiver Control Module																																																									
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																									
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																									
H	2015	Express	Body	Auxiliary Heater Control Module																																																									
H	2015	Express	Body	Remote Control Door Lock Receiver																																																									
H	2015	Express	Body	Parking Assist Control Module																																																									
H	2015	Express	Body	Theft Deterrent Module																																																									
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2015	Savana	Chassis	Electronic Brake Control Module																																																									
H	2015	Savana	Body	Body Control Module																																																									
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2015	Savana	Body	Rollover Sensor Module																																																								
H	2015	Savana	Body	Instrument Cluster																																																								
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																								
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																								
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																								
H	2015	Savana	Body	Auxiliary Heater Control Module																																																								
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																								
H	2015	Savana	Body	Parking Assist Control Module																																																								
H	2015	Savana	Body	Theft Deterrent Module																																																								
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
H	2016	Express	Chassis	Electronic Brake Control Module																																																								
H	2016	Express	Body	Body Control Module																																																								
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2016	Express	Body	Instrument Cluster																																																								
H	2016	Express	Body	Chime Alarm Control Module																																																								
H	2016	Express	Body	Base Radio																																																								
H	2016	Express	Body	Navigation Radio																																																								
H	2016	Express	Body	Uplevel Radio																																																								
H	2016	Express	Body	Digital Radio Receiver Control Module																																																								
H	2016	Express	Body	Telematics Communication Interface Control Module																																																								
H	2016	Express	Body	Auxiliary Heater Control Module																																																								
H	2016	Express	Body	Remote Control Door Lock Receiver																																																								
H	2016	Express	Body	Parking Assist Control Module																																																								
H	2016	Express	Body	Theft Deterrent Module																																																								
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
H	2016	Savana	Chassis	Electronic Brake Control Module																																																								
H	2016	Savana	Body	Body Control Module																																																								
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2016	Savana	Body	Instrument Cluster																																																								
H	2016	Savana	Body	Chime Alarm Control Module																																																								
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																								
H	2016	Savana	Body	Telematics Communication Interface Control Module																																																								
H	2016	Savana	Body	Auxiliary Heater Control Module																																																								
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																								
H	2016	Savana	Body	Parking Assist Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2016	Savana	Body	Theft Deterrent Module																																																								
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																																								
J	2004	ALL	Chassis	Electronic Brake Control Module																																																								
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																								
J	2007	ALL	Chassis	Electronic Brake Control Module																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																								
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																								
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																													V											
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																								
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Tracker	Chassis	Power Steering Control Module																																																								
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2013	Tracker	Body	Body Control Module																																																								
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2013	Tracker	Body	Passenger Presence Module																																																								
J	2013	Tracker	Body	Instrument Cluster																																																								
J	2013	Tracker	Body	Radio																																																								
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																																								
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																																								
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																																								
J	2013	Tracker	Body	Front Seat Heating Control Module																																																								
J	2013	Tracker	Body	Parking Assist Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2013	Tracker	Body	Frontview Camera Module																																																								
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																								
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																								
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																											V													
J	2013	Trax	Chassis	Electronic Brake Control Module																																																								
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Trax	Chassis	Power Steering Control Module																																																								
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2013	Trax	Body	Body Control Module																																																								
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2013	Trax	Body	Passenger Presence Module																																																								
J	2013	Trax	Body	Instrument Cluster																																																								
J	2013	Trax	Body	Radio																																																								
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																								
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
J	2013	Trax	Body	Front Seat Heating Control Module																																																								
J	2013	Trax	Body	Parking Assist Control Module																																																								
J	2013	Trax	Body	Frontview Camera Module																																																								
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																								
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																									
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																									
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																									
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																									
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																									
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																									
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																									
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																									
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																									
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																												V													
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																									
J	2014	Tracker	Chassis	Power Steering Control Module																																																									
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2014	Tracker	Body	Body Control Module																																																								
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2014	Tracker	Body	Passenger Presence Module																																																									
J	2014	Tracker	Body	Instrument Cluster																																																								
J	2014	Tracker	Body	Radio																																																								
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																																									
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																																									
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																									
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																																									
J	2014	Tracker	Body	Front Seat Heating Control Module																																																									
J	2014	Tracker	Body	Parking Assist Control Module																																																									
J	2014	Tracker	Body	Frontview Camera Module																																																									
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																									
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																								
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																								
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																												V												
J	2014	Trax	Chassis	Electronic Brake Control Module																																																								
J	2014	Trax	Chassis	Power Steering Control Module																																																								
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2014	Trax	Body	Body Control Module																																																							
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2014	Trax	Body	Passenger Presence Module																																																								
J	2014	Trax	Body	Instrument Cluster																																																								
J	2014	Trax	Body	Radio																																																								
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
J	2014	Trax	Body	Front Seat Heating Control Module																																																								
J	2014	Trax	Body	Parking Assist Control Module																																																								
J	2014	Trax	Body	Frontview Camera Module																																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																								
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																								
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																												V												
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																								
J	2015	Tracker	Chassis	Power Steering Control Module																																																								
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2015	Tracker	Body	Body Control Module																																																								
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Tracker	Body	Instrument Cluster																																																								
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																																								
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																																								
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																																								
J	2015	Tracker	Body	Front Seat Heating Control Module																																																								
J	2015	Tracker	Body	Parking Assist Control Module																																																								
J	2015	Tracker	Body	Frontview Camera Module																																																								
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																								
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																								
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																								
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																								
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																								
J	2015	Trax	Powertrain	Chassis Control Module																																																								
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																												V												
J	2015	Trax	Chassis	Electronic Brake Control Module																																																								
J	2015	Trax	Chassis	Power Steering Control Module																																																								
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2015	Trax	Body	Body Control Module																																																								
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2015	Trax	Body	Passenger Presence Module																																																								
J	2015	Trax	Body	Instrument Cluster																																																								
J	2015	Trax	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																								
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
J	2015	Trax	Body	Seat Memory Control Module																																																								
J	2015	Trax	Body	Front Seat Heating Control Module																																																								
J	2015	Trax	Body	Right Side Object Detection Control Module																																																								
J	2015	Trax	Body	Left Side Object Detection Control Module																																																								
J	2015	Trax	Body	Parking Assist Control Module																																																								
J	2015	Trax	Body	Frontview Camera Module																																																								
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																								
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																								
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																								
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																								
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																								
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																								
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																								
J	2016	Tracker	Chassis	Power Steering Control Module																																																								
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2016	Tracker	Body	Body Control Module																																																								
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2016	Tracker	Body	Instrument Cluster																																																								
J	2016	Tracker	Body	Trailer Interface Control Module																																																								
J	2016	Tracker	Body	Radio																																																								
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																																								
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																																								
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																																								
J	2016	Tracker	Body	Front Seat Heating Control Module																																																								
J	2016	Tracker	Body	Parking Assist Control Module																																																								
J	2016	Tracker	Body	Frontview Camera Module																																																								
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																								
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																								
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																								
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																								
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																								
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																								
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																								
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																								
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																								
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																								
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																								
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																								
J	2016	Trax	Powertrain	Chassis Control Module																																																								
J	2016	Trax	Chassis	Electronic Brake Control Module																																																								
J	2016	Trax	Chassis	Power Steering Control Module																																																								
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2016	Trax	Body	Body Control Module																																																								
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2016	Trax	Body	Passenger Presence Module																																																								
J	2016	Trax	Body	Instrument Cluster																																																								
J	2016	Trax	Body	Trailer Interface Control Module																																																								
J	2016	Trax	Body	Radio																																																								
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																								
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																								
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																								
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																								
J	2016	Trax	Body	Seat Memory Control Module																																																								
J	2016	Trax	Body	Front Seat Heating Control Module																																																								
J	2016	Trax	Body	Right Side Object Detection Control Module																																																								
J	2016	Trax	Body	Left Side Object Detection Control Module																																																								
J	2016	Trax	Body	Parking Assist Control Module																																																								
J	2016	Trax	Body	Frontview Camera Module																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																				V																																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																				V																																				
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																				
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																							
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																							
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																							
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																				V																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																							
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																							
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																							
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																							
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																							
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																				
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																							
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																							
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																							
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																							
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																							
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																							
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																							
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																							
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																							
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																							
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																							
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																							
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																							
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																							
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																						
K	2004	ALL	Chassis	ESC																																																						
K	2004	ALL	Chassis	Rear Wheel Steering																																																						
K	2004	ALL	Chassis	Tire Pressure Monitor																																														V									
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																						
K	2004	ALL	Chassis	VSES																																																						
K	2004	ALL	Body	Amplifier (Bose)																							V																															
K	2004	ALL	Body	Body Control Module																																																						
K	2004	ALL	Body	CD Changer																																																						
K	2004	ALL	Body	Chime																																																						
K	2004	ALL	Body	Driver Door Module																																																						
K	2004	ALL	Body	Driver Seat Module																								V																								V						
K	2004	ALL	Body	Heating and Air Conditioning Auto																								V																									V	V					
K	2004	ALL	Body	Heating and Air Conditioning Manual																								V																									V	V					
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																								V																									V	V					
K	2004	ALL	Body	Instrument Panel Cluster																V	V							V																															
K	2004	ALL	Body	OnStar																																																						
K	2004	ALL	Body	Passenger Door Module																																																			V	V			
K	2004	ALL	Body	Passenger Presence System																																																					V		
K	2004	ALL	Body	Radio Base																																																						
K	2004	ALL	Body	Radio Uplevel																																																						
K	2004	ALL	Body	Radio Navigation																																																						
K	2004	ALL	Body	Rear Aux. Climate Module																								V																									V					V
K	2004	ALL	Body	Rear HVAC																																																					

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2004	ALL	Body	Rear Seat Audio																																																								
K	2004	ALL	Body	Rear Seat Entertainment																																																								
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2004	ALL	Body	Vehicle Theft Deterrent																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																				V																																				
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																								
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																								
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																				V																																				
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																								
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																				V																																				
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																				
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																				V																																				
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																								
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																				
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																								
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																								
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
K	2005	ALL	Chassis	ESC																																																								
K	2005	ALL	Chassis	Rear Wheel Steering																																																								
K	2005	ALL	Chassis	Tire Pressure Monitor																																															V								
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																								
K	2005	ALL	Chassis	VSES																																																								
K	2005	ALL	Body	Amplifier (Bose)																							V																																		
K	2005	ALL	Body	Body Control Module																																																								
K	2005	ALL	Body	CD Changer																																																								
K	2005	ALL	Body	Chime																																																								
K	2005	ALL	Body	Disc Player and Video Display																																																								
K	2005	ALL	Body	Driver Door Module																																																								
K	2005	ALL	Body	Driver Seat Module																								V																								V								
K	2005	ALL	Body	Generator Battery Control Module																																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto																								V																										V	V						
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																								V																										V	V						
K	2005	ALL	Body	Heating and Air Conditioning Manual																								V																										V	V						
K	2005	ALL	Body	Instrument Panel Cluster																V	V							V																																	
K	2005	ALL	Body	Passenger Door Module																																																				V	V		
K	2005	ALL	Body	Passenger Presence System																																																					V		
K	2005	ALL	Body	Base Radio																																																								
K	2005	ALL	Body	Uplevel Radio																																																								
K	2005	ALL	Body	Navigation Radio																																																								
K	2005	ALL	Body	Rear Aux. Climate Module																								V																										V						V
K	2005	ALL	Body	Rear HVAC																																																								
K	2005	ALL	Body	Rear Seat Audio																																																								
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2005	ALL	Body	Vehicle Theft Deterrent																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																				V																																				
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																				V																																				
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																				V																																				

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																					
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																					
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																				V																																					
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																					
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																								
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																								
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																								
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																								
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
K	2006	ALL	Chassis	ESC																																																							
K	2006	ALL	Chassis	Tire Pressure Monitor																																															V									
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																								
K	2006	ALL	Chassis	VSES																																																							
K	2006	ALL	Body	Amplifier (Bose)																							V																																	
K	2006	ALL	Body	Body Control Module																																																								
K	2006	ALL	Body	CD Changer																																																								
K	2006	ALL	Body	Chime																																																								
K	2006	ALL	Body	Disc Player and Video Display																																																								
K	2006	ALL	Body	Driver Door Module																																																								
K	2006	ALL	Body	Driver Seat Module																								V																								V								
K	2006	ALL	Body	Generator Battery Control Module																																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto																								V																										V	V						

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																								V																											V	V				
K	2006	ALL	Body	Heating and Air Conditioning Manual																								V																											V	V				
K	2006	ALL	Body	Instrument Panel Cluster																V	V							V																																
K	2006	ALL	Body	Passenger Door Module																																																					V	V		
K	2006	ALL	Body	Passenger Presence System																																																							V	
K	2006	ALL	Body	Base Radio																																																								
K	2006	ALL	Body	Uplevel Radio																																																								
K	2006	ALL	Body	Navigation Radio																																																								
K	2006	ALL	Body	Rear Aux. Climate Module																								V																											V					V
K	2006	ALL	Body	Rear HVAC																																																								
K	2006	ALL	Body	Rear Seat Audio																																																								
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2006	ALL	Body	Vehicle Theft Deterrent																																																								
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																													
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																		
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V	V																																													
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																		
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																													
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module					V						V																																													
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																		
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2007	Avalanche	Chassis	Electronic Suspension Control																																																								
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																																								
K	2007	Avalanche	Body	Amplifier (Bose)																																																								
K	2007	Avalanche	Body	Assist Step Controller																																																								
K	2007	Avalanche	Body	Body Control Module																																																								
K	2007	Avalanche	Body	Body Control Module (aux.)																																																								
K	2007	Avalanche	Body	Digital Radio Receiver																																																								
K	2007	Avalanche	Body	Driver Door Switch																																																								
K	2007	Avalanche	Body	HVAC Control Module Auto									V																																															
K	2007	Avalanche	Body	HVAC Control Module Manual																																																								
K	2007	Avalanche	Body	Instrument Panel Cluster																																																								
K	2007	Avalanche	Body	Memory Seat Module																																																								
K	2007	Avalanche	Body	Park Assist Module																																																								
K	2007	Avalanche	Body	Passenger Door Switch																																																								
K	2007	Avalanche	Body	Passenger Presence System																																																								
K	2007	Avalanche	Body	Radio																																																								
K	2007	Avalanche	Body	Rear Heated Seat Module																																																								
K	2007	Avalanche	Body	Rear HVAC/RSA																																																								
K	2007	Avalanche	Body	Rollover Sensor																																																								
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																								
K	2007	Avalanche	Body	Theft Deterrent Module																																																								
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																													

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																			
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V	V																																														
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																			
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																														
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																			
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																														
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module					V						V																																														
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																				
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Suburban	Chassis	Electronic Suspension Control																																																									
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																									
K	2007	Suburban	Body	Amplifier (Bose)																																																									
K	2007	Suburban	Body	Assist Step Controller																																																									
K	2007	Suburban	Body	Body Control Module																																																									
K	2007	Suburban	Body	Body Control Module (aux.)																																																									
K	2007	Suburban	Body	Digital Radio Receiver																																																									
K	2007	Suburban	Body	Driver Door Switch																																																									
K	2007	Suburban	Body	HVAC Control Module Auto									V																																																
K	2007	Suburban	Body	HVAC Control Module Manual																																																									
K	2007	Suburban	Body	Instrument Panel Cluster																																																									
K	2007	Suburban	Body	Lift Gate Module																																																									
K	2007	Suburban	Body	Memory Seat Module																																																									
K	2007	Suburban	Body	Park Assist Module																																																									
K	2007	Suburban	Body	Passenger Door Switch																																																									
K	2007	Suburban	Body	Passenger Presence System																																																									
K	2007	Suburban	Body	Radio																																																									
K	2007	Suburban	Body	Rear Heated Seat Module																																																									
K	2007	Suburban	Body	Rear HVAC/RSA																																																									
K	2007	Suburban	Body	Rollover Sensor																																																									
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																																									
K	2007	Suburban	Body	Theft Deterrent Module																																																									
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module											V																																														
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																									
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																			
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																														
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																									
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																			
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																														
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																			
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V	V																																														
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																			
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																														
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																			
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V	V																																														
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																			
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																														
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module					V						V																																														
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																			
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module											V																																														
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																									
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Silverado	Chassis	Electronic Suspension Control																																																									
K	2007	Silverado	Chassis	Trailer Brake Control Module																																																									
K	2007	Silverado	Body	Amplifier (Bose)																																																									
K	2007	Silverado	Body	Body Control Module																																																									
K	2007	Silverado	Body	Body Control Module (aux.)																																																									
K	2007	Silverado	Body	Digital Radio Receiver																																																									
K	2007	Silverado	Body	Driver Door Switch																																																									
K	2007	Silverado	Body	HVAC Control Module Auto									V																																															
K	2007	Silverado	Body	HVAC Control Module Manual																																																									
K	2007	Silverado	Body	Instrument Panel Cluster																																																									
K	2007	Silverado	Body	Memory Seat Module																																																									
K	2007	Silverado	Body	Park Assist Module																																																									
K	2007	Silverado	Body	Passenger Door Switch																																																									
K	2007	Silverado	Body	Passenger Presence System																																																									
K	2007	Silverado	Body	Radio																																																									
K	2007	Silverado	Body	Rear Heated Seat Module																																																									
K	2007	Silverado	Body	Rear HVAC/RSA																																																									
K	2007	Silverado	Body	Rollover Sensor																																																									
K	2007	Silverado	Body	Supplemental Inflatable Restraint																																																									
K	2007	Silverado	Body	Theft Deterrent Module																																																									
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																														
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																									
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																			
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																														
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																			
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																														

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																								
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																								
K	2007	Tahoe	Body	Amplifier (Bose)																																																								
K	2007	Tahoe	Body	Assist Step Controller																																																								
K	2007	Tahoe	Body	Body Control Module																																																								
K	2007	Tahoe	Body	Body Control Module (aux.)																																																								
K	2007	Tahoe	Body	Digital Radio Receiver																																																								
K	2007	Tahoe	Body	Driver Door Switch																																																								
K	2007	Tahoe	Body	HVAC Control Module Auto									V																																															
K	2007	Tahoe	Body	HVAC Control Module Manual																																																								
K	2007	Tahoe	Body	Instrument Panel Cluster																																																								
K	2007	Tahoe	Body	Lift Gate Module																																																								
K	2007	Tahoe	Body	Memory Seat Module																																																								
K	2007	Tahoe	Body	Park Assist Module																																																								
K	2007	Tahoe	Body	Passenger Door Switch																																																								
K	2007	Tahoe	Body	Passenger Presence System																																																								
K	2007	Tahoe	Body	Radio																																																								
K	2007	Tahoe	Body	Rear Heated Seat Module																																																								
K	2007	Tahoe	Body	Rear HVAC/RSA																																																								
K	2007	Tahoe	Body	Rollover Sensor																																																								
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																								
K	2007	Tahoe	Body	Theft Deterrent Module																																																								
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																		
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																		
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																														
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																														
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																		
K	2008	Avalanche	Chassis	Electronic Brake Control Module																																																								
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																								
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																								
K	2008	Avalanche	Body	Amplifier (Bose)																																																								
K	2008	Avalanche	Body	Assist Step Controller																																																								
K	2008	Avalanche	Body	Body Control Module																																																								
K	2008	Avalanche	Body	Body Control Module (aux.)																																																								
K	2008	Avalanche	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2008	Avalanche	Body	Driver Door Switch																																																								
K	2008	Avalanche	Body	HVAC Control Module Auto									V																																																
K	2008	Avalanche	Body	HVAC Control Module Manual																																																										
K	2008	Avalanche	Body	Instrument Panel Cluster																																																										
K	2008	Avalanche	Body	Memory Seat Module																																																										
K	2008	Avalanche	Body	Park Assist Module																																																										
K	2008	Avalanche	Body	Passenger Door Switch																																																										
K	2008	Avalanche	Body	Passenger Presence System																																																										
K	2008	Avalanche	Body	Radio																																																										
K	2008	Avalanche	Body	Rear Heated Seat Module																																																										
K	2008	Avalanche	Body	Rear HVAC/RSA																																																										
K	2008	Avalanche	Body	Rollover Sensor																																																										
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2008	Avalanche	Body	Theft Deterrent Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																															
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																			
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V	V																																															
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																			
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																			
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																															
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																			
K	2008	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Suburban	Chassis	Electronic Suspension Control																																																										
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																										
K	2008	Suburban	Body	Amplifier (Bose)																																																										
K	2008	Suburban	Body	Assist Step Controller																																																										
K	2008	Suburban	Body	Body Control Module																																																										
K	2008	Suburban	Body	Body Control Module (aux.)																																																										
K	2008	Suburban	Body	Digital Radio Receiver																																																										
K	2008	Suburban	Body	Driver Door Switch																																																										
K	2008	Suburban	Body	HVAC Control Module Auto									V																																																	
K	2008	Suburban	Body	HVAC Control Module Manual																																																										
K	2008	Suburban	Body	Instrument Panel Cluster																																																										
K	2008	Suburban	Body	Lift Gate Module																																																										
K	2008	Suburban	Body	Memory Seat Module																																																										
K	2008	Suburban	Body	Park Assist Module																																																										
K	2008	Suburban	Body	Passenger Door Switch																																																										
K	2008	Suburban	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2008	Suburban	Body	Radio																																																								
K	2008	Suburban	Body	Rear Heated Seat Module																																																								
K	2008	Suburban	Body	Rear HVAC/RSA																																																								
K	2008	Suburban	Body	Rollover Sensor																																																								
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																																								
K	2008	Suburban	Body	Theft Deterrent Module																																																								
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																		
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																		
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																		
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																		
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																														
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																														
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																		
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																													
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																														
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																		
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module											V																																													
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2008	Silverado	Chassis	Electronic Suspension Control																																																								
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																								
K	2008	Silverado	Body	Amplifier (Bose)																																																								
K	2008	Silverado	Body	Body Control Module																																																								
K	2008	Silverado	Body	Body Control Module (aux.)																																																								
K	2008	Silverado	Body	Digital Radio Receiver																																																								
K	2008	Silverado	Body	Driver Door Switch																																																								
K	2008	Silverado	Body	HVAC Control Module Auto									V																																															
K	2008	Silverado	Body	HVAC Control Module Manual																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2008	Silverado	Body	Instrument Panel Cluster																																																								
K	2008	Silverado	Body	Memory Seat Module																																																								
K	2008	Silverado	Body	Park Assist Module																																																								
K	2008	Silverado	Body	Passenger Door Switch																																																								
K	2008	Silverado	Body	Passenger Presence System																																																								
K	2008	Silverado	Body	Radio																																																								
K	2008	Silverado	Body	Rear Heated Seat Module																																																								
K	2008	Silverado	Body	Rear HVAC/RSA																																																								
K	2008	Silverado	Body	Rollover Sensor																																																								
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																																								
K	2008	Silverado	Body	Theft Deterrent Module																																																								
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																		
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																		
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																														
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
K	2008	Tahoe	Chassis	Electronic Brake Control Module																																																								
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																								
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																								
K	2008	Tahoe	Body	Amplifier (Bose)																																																								
K	2008	Tahoe	Body	Assist Step Controller																																																								
K	2008	Tahoe	Body	Body Control Module																																																								
K	2008	Tahoe	Body	Body Control Module (aux.)																																																								
K	2008	Tahoe	Body	Digital Radio Receiver																																																								
K	2008	Tahoe	Body	Driver Door Switch																																																								
K	2008	Tahoe	Body	HVAC Control Module Auto									V																																														
K	2008	Tahoe	Body	HVAC Control Module Manual																																																								
K	2008	Tahoe	Body	Instrument Panel Cluster																																																								
K	2008	Tahoe	Body	Lift Gate Module																																																								
K	2008	Tahoe	Body	Memory Seat Module																																																								
K	2008	Tahoe	Body	Park Assist Module																																																								
K	2008	Tahoe	Body	Passenger Door Switch																																																								
K	2008	Tahoe	Body	Passenger Presence System																																																								
K	2008	Tahoe	Body	Radio																																																								
K	2008	Tahoe	Body	Rear Heated Seat Module																																																								
K	2008	Tahoe	Body	Rear HVAC/RSA																																																								
K	2008	Tahoe	Body	Rollover Sensor																																																								
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																								
K	2008	Tahoe	Body	Theft Deterrent Module																																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																									
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																									
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																									
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
K	2008	Tahoe Hybrid	Body	Body Control Module																																																									
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																																									
K	2008	Tahoe Hybrid	Body	HVAC Control Module									V																																																
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																									
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																									
K	2008	Tahoe Hybrid	Body	Memory Seat Module																																																									
K	2008	Tahoe Hybrid	Body	Park Assist Module																																																									
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																									
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																																									
K	2008	Tahoe Hybrid	Body	Radio																																																									
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																									
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																									
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																									
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																									
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																									
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																															
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																															
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																								
K	2009	Avalanche	Body	Amplifier (Bose)																																																									
K	2009	Avalanche	Body	Assist Step Controller																																																									
K	2009	Avalanche	Body	Body Control Module																																																									
K	2009	Avalanche	Body	Body Control Module (aux.)																																																									
K	2009	Avalanche	Body	Digital Radio Receiver																																																									
K	2009	Avalanche	Body	Driver Door Switch																																																									
K	2009	Avalanche	Body	HVAC Control Module Auto									V																																																
K	2009	Avalanche	Body	HVAC Control Module Manual																																																										
K	2009	Avalanche	Body	Instrument Panel Cluster																																																										
K	2009	Avalanche	Body	Memory Seat Module																																																										
K	2009	Avalanche	Body	Park Assist Module																																																										
K	2009	Avalanche	Body	Passenger Door Switch																																																										
K	2009	Avalanche	Body	Passenger Presence System																																																										
K	2009	Avalanche	Body	Radio																																																										
K	2009	Avalanche	Body	Rear Heated Seat Module																																																										
K	2009	Avalanche	Body	Rear HVAC/RSA																																																										
K	2009	Avalanche	Body	Rollover Sensor																																																										
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2009	Avalanche	Body	Theft Deterrent Module																																																										
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																															
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																															
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																										
K	2009	Cheyenne	Body	Amplifier (Bose)																																																										
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2009	Cheyenne	Body	Digital Radio Receiver																																																										
K	2009	Cheyenne	Body	Driver Door Switch																																																										
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2009	Cheyenne	Body	Park Assist Module																																																										
K	2009	Cheyenne	Body	Passenger Door Switch																																																										
K	2009	Cheyenne	Body	Passenger Presence System																																																										
K	2009	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2009	Cheyenne	Body	Rollover Sensor																																																										
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2009	Cheyenne	Body	Theft Deterrent Module																																																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																														
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V	V																																														
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																															
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																														
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																															
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
K	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																									
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2009	Suburban	Chassis	Electronic Suspension Control																																																								
K	2009	Suburban	Chassis	Trailer Brake Control Module																																																								
K	2009	Suburban	Body	Amplifier (Bose)																																																								
K	2009	Suburban	Body	Assist Step Controller																																																								
K	2009	Suburban	Body	Body Control Module																																																								
K	2009	Suburban	Body	Body Control Module (aux.)																																																								
K	2009	Suburban	Body	Digital Radio Receiver																																																								
K	2009	Suburban	Body	Driver Door Switch																																																								
K	2009	Suburban	Body	HVAC Control Module Auto									V																																															
K	2009	Suburban	Body	HVAC Control Module Manual																																																								
K	2009	Suburban	Body	Instrument Panel Cluster																																																								
K	2009	Suburban	Body	Left Side Object Detection Module																																																								
K	2009	Suburban	Body	Lift Gate Module																																																								
K	2009	Suburban	Body	Memory Seat Module																																																								
K	2009	Suburban	Body	Park Assist Module																																																								
K	2009	Suburban	Body	Passenger Door Switch																																																								
K	2009	Suburban	Body	Passenger Presence System																																																								
K	2009	Suburban	Body	Radio																																																								
K	2009	Suburban	Body	Rear Heated Seat Module																																																								
K	2009	Suburban	Body	Rear HVAC/RSA																																																								
K	2009	Suburban	Body	Right Side Object Detection Module																																																								
K	2009	Suburban	Body	Rollover Sensor																																																								
K	2009	Suburban	Body	Supplemental Inflatable Restraint																																																								
K	2009	Suburban	Body	Theft Deterrent Module																																																								
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																								
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																								
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																														
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																								
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																								
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																														
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																														
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																								
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																								
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																								
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
K	2009	Silverado	Chassis	Electronic Suspension Control																																																								
K	2009	Silverado	Chassis	Trailer Brake Control Module																																																								
K	2009	Silverado	Body	Amplifier (Bose)																																																								
K	2009	Silverado	Body	Body Control Module																																																								
K	2009	Silverado	Body	Body Control Module (aux.)																																																								
K	2009	Silverado	Body	Digital Radio Receiver																																																								
K	2009	Silverado	Body	Driver Door Switch																																																								
K	2009	Silverado	Body	HVAC Control Module Auto										V																																														
K	2009	Silverado	Body	HVAC Control Module Manual																																																								
K	2009	Silverado	Body	Instrument Panel Cluster																																																								
K	2009	Silverado	Body	Memory Seat Module																																																								
K	2009	Silverado	Body	Park Assist Module																																																								
K	2009	Silverado	Body	Passenger Door Switch																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2009	Silverado	Body	Passenger Presence System																																																								
K	2009	Silverado	Body	Radio																																																								
K	2009	Silverado	Body	Rear Heated Seat Module																																																								
K	2009	Silverado	Body	Rear HVAC/RSA																																																								
K	2009	Silverado	Body	Rollover Sensor																																																								
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																																								
K	2009	Silverado	Body	Theft Deterrent Module																																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																								
K	2009	Silverado Hybrid	Body	Body Control Module																																																								
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																								
K	2009	Silverado Hybrid	Body	Driver Door Switch																																																								
K	2009	Silverado Hybrid	Body	HVAC Control Module									V																																															
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
K	2009	Silverado Hybrid	Body	Memory Seat Module																																																								
K	2009	Silverado Hybrid	Body	Park Assist Module																																																								
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																																								
K	2009	Silverado Hybrid	Body	Passenger Presence System																																																								
K	2009	Silverado Hybrid	Body	Radio																																																								
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																								
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																								
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																								
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																															
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2009	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2009	Tahoe	Body	Amplifier (Bose)																																																										
K	2009	Tahoe	Body	Assist Step Controller																																																										
K	2009	Tahoe	Body	Body Control Module																																																										
K	2009	Tahoe	Body	Body Control Module (aux.)																																																										
K	2009	Tahoe	Body	Digital Radio Receiver																																																										
K	2009	Tahoe	Body	Driver Door Switch																																																										
K	2009	Tahoe	Body	HVAC Control Module Auto									V																																																
K	2009	Tahoe	Body	HVAC Control Module Manual																																																										
K	2009	Tahoe	Body	Instrument Panel Cluster																																																										
K	2009	Tahoe	Body	Left Side Object Detection Module																																																										
K	2009	Tahoe	Body	Lift Gate Module																																																										
K	2009	Tahoe	Body	Memory Seat Module																																																										
K	2009	Tahoe	Body	Park Assist Module																																																										
K	2009	Tahoe	Body	Passenger Door Switch																																																										
K	2009	Tahoe	Body	Passenger Presence System																																																										
K	2009	Tahoe	Body	Radio																																																										
K	2009	Tahoe	Body	Rear Heated Seat Module																																																										
K	2009	Tahoe	Body	Rear HVAC/RSA																																																										
K	2009	Tahoe	Body	Right Side Object Detection Module																																																										
K	2009	Tahoe	Body	Rollover Sensor																																																										
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2009	Tahoe	Body	Theft Deterrent Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																					
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Tahoe Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2009	Tahoe Hybrid	Body	HVAC Control Module									V																																																	
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2009	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2009	Tahoe Hybrid	Body	Radio																																																										
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																										
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Avalanche	Chassis	Electronic Brake Control Module																																																										
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Avalanche	Body	Amplifier (Bose)																																																										
K	2010	Avalanche	Body	Assist Step Controller																																																										
K	2010	Avalanche	Body	Body Control Module																																																										
K	2010	Avalanche	Body	Body Control Module (aux.)																																																										
K	2010	Avalanche	Body	Digital Radio Receiver																																																										
K	2010	Avalanche	Body	Driver Door Switch																																																										
K	2010	Avalanche	Body	HVAC Control Module Auto									V																																																	
K	2010	Avalanche	Body	HVAC Control Module Manual																																																										
K	2010	Avalanche	Body	Instrument Panel Cluster																																																										
K	2010	Avalanche	Body	Memory Seat Module																																																										
K	2010	Avalanche	Body	Park Assist Module																																																										
K	2010	Avalanche	Body	Passenger Door Switch																																																										
K	2010	Avalanche	Body	Passenger Presence System																																																										
K	2010	Avalanche	Body	Radio																																																										
K	2010	Avalanche	Body	Rear Heated Seat Module																																																										
K	2010	Avalanche	Body	Rear HVAC/RSA																																																										
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2010	Avalanche	Body	Theft Deterrent Module																																																										
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Cheyenne	Body	Amplifier (Bose)																																																										
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2010	Cheyenne	Body	Digital Radio Receiver																																																										
K	2010	Cheyenne	Body	Driver Door Switch																																																										
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2010	Cheyenne	Body	Park Assist Module																																																										
K	2010	Cheyenne	Body	Passenger Door Switch																																																										
K	2010	Cheyenne	Body	Passenger Presence System																																																										
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2010	Cheyenne	Body	Theft Deterrent Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2010	Suburban	Chassis	Electronic Suspension Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Body	Amplifier (Bose)																																																										
K	2010	Suburban	Body	Assist Step Controller																																																										
K	2010	Suburban	Body	Body Control Module																																																										
K	2010	Suburban	Body	Body Control Module (aux.)																																																										
K	2010	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2010	Suburban	Body	Driver Door Switch																																																								
K	2010	Suburban	Body	HVAC Control Module Auto									V																																																
K	2010	Suburban	Body	HVAC Control Module Manual																																																										
K	2010	Suburban	Body	Instrument Panel Cluster																																																										
K	2010	Suburban	Body	Left Side Object Detection Module																																																										
K	2010	Suburban	Body	Lift Gate Module																																																										
K	2010	Suburban	Body	Memory Seat Module																																																										
K	2010	Suburban	Body	Park Assist Module																																																										
K	2010	Suburban	Body	Passenger Door Switch																																																										
K	2010	Suburban	Body	Passenger Presence System																																																										
K	2010	Suburban	Body	Radio																																																										
K	2010	Suburban	Body	Rear Heated Seat Module																																																										
K	2010	Suburban	Body	Rear HVAC/RSA																																																										
K	2010	Suburban	Body	Right Side Object Detection Module																																																										
K	2010	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2010	Suburban	Body	Theft Deterrent Module																																																										
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																						V																				
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																						V																				
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																						V																				
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																						V																				
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
K	2010	Silverado	Chassis	Electronic Suspension Control																																																									
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
K	2010	Silverado	Body	Amplifier (Bose)																																																									
K	2010	Silverado	Body	Body Control Module																																																									
K	2010	Silverado	Body	Body Control Module (aux.)																																																									
K	2010	Silverado	Body	Digital Radio Receiver																																																									
K	2010	Silverado	Body	Driver Door Switch																																																									
K	2010	Silverado	Body	HVAC Control Module Auto									V																																																
K	2010	Silverado	Body	HVAC Control Module Manual									V																																																
K	2010	Silverado	Body	Instrument Panel Cluster																																																									
K	2010	Silverado	Body	Memory Seat Module																																																									
K	2010	Silverado	Body	Park Assist Module																																																									
K	2010	Silverado	Body	Passenger Door Switch																																																									
K	2010	Silverado	Body	Passenger Presence System																																																									
K	2010	Silverado	Body	Radio																																																									
K	2010	Silverado	Body	Rear Heated Seat Module																																																									
K	2010	Silverado	Body	Rear HVAC/RSA																																																									
K	2010	Silverado	Body	Supplemental Inflatable Restraint																																																									
K	2010	Silverado	Body	Theft Deterrent Module																																																									
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																				
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																									
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																									
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																									
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																									
K	2010	Silverado Hybrid	Body	Body Control Module																																																									
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																									
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																									
K	2010	Silverado Hybrid	Body	Driver Door Switch																																																									
K	2010	Silverado Hybrid	Body	Heated Seat Module																																																									
K	2010	Silverado Hybrid	Body	HVAC Control Module																																																									
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																									
K	2010	Silverado Hybrid	Body	Park Assist Module																																																									
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																																									
K	2010	Silverado Hybrid	Body	Passenger Presence System																																																									
K	2010	Silverado Hybrid	Body	Radio																																																									
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																									
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																									
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																									
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2010	Tahoe	Chassis	Electronic Brake Control Module																																																								
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																								
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Tahoe	Body	Amplifier (Bose)																																																								
K	2010	Tahoe	Body	Assist Step Controller																																																								
K	2010	Tahoe	Body	Body Control Module																																																								
K	2010	Tahoe	Body	Body Control Module (aux.)																																																								
K	2010	Tahoe	Body	Digital Radio Receiver																																																								
K	2010	Tahoe	Body	Driver Door Switch																																																								
K	2010	Tahoe	Body	HVAC Control Module Auto									V																																															
K	2010	Tahoe	Body	HVAC Control Module Manual																																																								
K	2010	Tahoe	Body	Instrument Panel Cluster																																																								
K	2010	Tahoe	Body	Left Side Object Detection Module																																																								
K	2010	Tahoe	Body	Lift Gate Module																																																								
K	2010	Tahoe	Body	Memory Seat Module																																																								
K	2010	Tahoe	Body	Park Assist Module																																																								
K	2010	Tahoe	Body	Passenger Door Switch																																																								
K	2010	Tahoe	Body	Passenger Presence System																																																								
K	2010	Tahoe	Body	Radio																																																								
K	2010	Tahoe	Body	Rear Heated Seat Module																																																								
K	2010	Tahoe	Body	Rear HVAC/RSA																																																								
K	2010	Tahoe	Body	Right Side Object Detection Module																																																								
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																								
K	2010	Tahoe	Body	Theft Deterrent Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																								
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																								
K	2010	Tahoe Hybrid	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																								
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																								
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																																								
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																																								
K	2010	Tahoe Hybrid	Body	HVAC Control Module																																																								
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																																								
K	2010	Tahoe Hybrid	Body	Park Assist Module																																																								
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																								
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																																								
K	2010	Tahoe Hybrid	Body	Radio																																																								
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module										V																																														
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module										V																																														
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2011	Avalanche	Chassis	Electronic Brake Control Module																																																								
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																								
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
K	2011	Avalanche	Body	Amplifier (Bose)																																																								
K	2011	Avalanche	Body	Assist Step Controller																																																								
K	2011	Avalanche	Body	Body Control Module																																																								
K	2011	Avalanche	Body	Body Control Module (aux.)																																																								
K	2011	Avalanche	Body	Digital Radio Receiver																																																								
K	2011	Avalanche	Body	Driver Door Switch																																																								
K	2011	Avalanche	Body	HVAC Control Module Auto									V																																															
K	2011	Avalanche	Body	HVAC Control Module Manual																																																								
K	2011	Avalanche	Body	Instrument Panel Cluster																																																								
K	2011	Avalanche	Body	Memory Seat Module																																																								
K	2011	Avalanche	Body	Park Assist Module																																																								
K	2011	Avalanche	Body	Passenger Door Switch																																																								
K	2011	Avalanche	Body	Passenger Presence System																																																								
K	2011	Avalanche	Body	Radio																																																								
K	2011	Avalanche	Body	Rear Heated Seat Module																																																								
K	2011	Avalanche	Body	Rear HVAC/RSA																																																								
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																								
K	2011	Avalanche	Body	Theft Deterrent Module																																																								
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																								
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																								
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																								
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																								
K	2011	Cheyenne	Body	Amplifier (Bose)																																																								
K	2011	Cheyenne	Body	Body Control Module																																																								
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																								
K	2011	Cheyenne	Body	Digital Radio Receiver																																																								
K	2011	Cheyenne	Body	Driver Door Switch																																																								
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																								
K	2011	Cheyenne	Body	Park Assist Module																																																								
K	2011	Cheyenne	Body	Passenger Door Switch																																																								
K	2011	Cheyenne	Body	Passenger Presence System																																																								
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																								
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																								
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																								
K	2011	Cheyenne	Body	Theft Deterrent Module																																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
K	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																								
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2011	Suburban	Chassis	Electronic Suspension Control																																																								
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																								
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																								
K	2011	Suburban	Body	Amplifier (Bose)																																																								
K	2011	Suburban	Body	Assist Step Controller																																																								
K	2011	Suburban	Body	Body Control Module																																																								
K	2011	Suburban	Body	Body Control Module (aux.)																																																								
K	2011	Suburban	Body	Digital Radio Receiver																																																								
K	2011	Suburban	Body	Driver Door Switch																																																								
K	2011	Suburban	Body	HVAC Control Module Auto									V																																														
K	2011	Suburban	Body	HVAC Control Module Manual																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2011	Suburban	Body	Instrument Panel Cluster																																																								
K	2011	Suburban	Body	Left Side Object Detection Module																																																								
K	2011	Suburban	Body	Lift Gate Module																																																								
K	2011	Suburban	Body	Memory Seat Module																																																								
K	2011	Suburban	Body	Park Assist Module																																																								
K	2011	Suburban	Body	Passenger Door Switch																																																								
K	2011	Suburban	Body	Passenger Presence System																																																								
K	2011	Suburban	Body	Radio																																																								
K	2011	Suburban	Body	Rear Heated Seat Module																																																								
K	2011	Suburban	Body	Rear HVAC/RSA																																																								
K	2011	Suburban	Body	Right Side Object Detection Module																																																								
K	2011	Suburban	Body	Supplemental Inflatable Restraint																																																								
K	2011	Suburban	Body	Theft Deterrent Module																																																								
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																						V																		
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																						V																		
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module										V																																													
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module										V																																													
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																													
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																								
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																						V																		
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module											V																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																								
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
K	2011	Silverado	Chassis	Electronic Suspension Control																																																									
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
K	2011	Silverado	Body	Amplifier (Bose)																																																									
K	2011	Silverado	Body	Body Control Module																																																									
K	2011	Silverado	Body	Body Control Module (aux.)																																																									
K	2011	Silverado	Body	Digital Radio Receiver																																																									
K	2011	Silverado	Body	Driver Door Switch																																																									
K	2011	Silverado	Body	HVAC Control Module Auto									V																																																
K	2011	Silverado	Body	HVAC Control Module Manual									V																																																
K	2011	Silverado	Body	Instrument Panel Cluster																																																									
K	2011	Silverado	Body	Memory Seat Module																																																									
K	2011	Silverado	Body	Park Assist Module																																																									
K	2011	Silverado	Body	Passenger Door Switch																																																									
K	2011	Silverado	Body	Passenger Presence System																																																									
K	2011	Silverado	Body	Radio																																																									
K	2011	Silverado	Body	Rear Heated Seat Module																																																									
K	2011	Silverado	Body	Rear HVAC/RSA																																																									
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																																									
K	2011	Silverado	Body	Theft Deterrent Module																																																									
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																				
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																									
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																									
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																									
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																									
K	2011	Silverado Hybrid	Body	Body Control Module																																																									
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																									
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																									
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																									
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																									
K	2011	Silverado Hybrid	Body	HVAC Control Module																																																									
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																									
K	2011	Silverado Hybrid	Body	Park Assist Module																																																									
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																									
K	2011	Silverado Hybrid	Body	Passenger Presence System																																																									
K	2011	Silverado Hybrid	Body	Radio																																																									
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																									
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																									
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																									
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																								
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																									
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																									
K	2011	Tahoe	Chassis	Electronic Brake Control Module																																																									
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																									
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
K	2011	Tahoe	Body	Amplifier (Bose)																																																									
K	2011	Tahoe	Body	Assist Step Controller																																																									
K	2011	Tahoe	Body	Body Control Module																																																									
K	2011	Tahoe	Body	Body Control Module (aux.)																																																									
K	2011	Tahoe	Body	Digital Radio Receiver																																																									
K	2011	Tahoe	Body	Driver Door Switch																																																									
K	2011	Tahoe	Body	HVAC Control Module Auto									V																																																
K	2011	Tahoe	Body	HVAC Control Module Manual																																																									
K	2011	Tahoe	Body	Instrument Panel Cluster																																																									
K	2011	Tahoe	Body	Left Side Object Detection Module																																																									
K	2011	Tahoe	Body	Lift Gate Module																																																									
K	2011	Tahoe	Body	Memory Seat Module																																																									
K	2011	Tahoe	Body	Park Assist Module																																																									
K	2011	Tahoe	Body	Passenger Door Switch																																																									
K	2011	Tahoe	Body	Passenger Presence System																																																									
K	2011	Tahoe	Body	Radio																																																									
K	2011	Tahoe	Body	Rear Heated Seat Module																																																									
K	2011	Tahoe	Body	Rear HVAC/RSA																																																									
K	2011	Tahoe	Body	Right Side Object Detection Module																																																									
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																									
K	2011	Tahoe	Body	Theft Deterrent Module																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																				
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
K	2011	Tahoe Hybrid	Body	Body Control Module																																																									
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																																									
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																																									
K	2011	Tahoe Hybrid	Body	HVAC Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																																								
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																								
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																								
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																																								
K	2011	Tahoe Hybrid	Body	Radio																																																								
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																														
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2012	Avalanche	Chassis	Electronic Brake Control Module																																																								
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																								
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
K	2012	Avalanche	Body	Amplifier (Bose)																																																								
K	2012	Avalanche	Body	Assist Step Controller																																																								
K	2012	Avalanche	Body	Body Control Module																																																								
K	2012	Avalanche	Body	Body Control Module (aux.)																																																								
K	2012	Avalanche	Body	Digital Radio Receiver																																																								
K	2012	Avalanche	Body	Driver Door Switch																																																								
K	2012	Avalanche	Body	HVAC Control Module Auto									V																																															
K	2012	Avalanche	Body	HVAC Control Module Manual																																																								
K	2012	Avalanche	Body	Instrument Panel Cluster																																																								
K	2012	Avalanche	Body	Memory Seat Module																																																								
K	2012	Avalanche	Body	Navigation Radio																																																								
K	2012	Avalanche	Body	Park Assist Module																																																								
K	2012	Avalanche	Body	Passenger Door Switch																																																								
K	2012	Avalanche	Body	Passenger Presence System																																																								
K	2012	Avalanche	Body	Radio																																																								
K	2012	Avalanche	Body	Rear Heated Seat Module																																																								
K	2012	Avalanche	Body	Rear HVAC/RSA																																																								
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																								
K	2012	Avalanche	Body	Theft Deterrent Module																																																								
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																					V																			
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																					V																			
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																															
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Cheyenne	Body	Amplifier (Bose)																																																										
K	2012	Cheyenne	Body	Body Control Module																																																										
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2012	Cheyenne	Body	Digital Radio Receiver																																																										
K	2012	Cheyenne	Body	Driver Door Switch																																																										
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2012	Cheyenne	Body	Park Assist Module																																																										
K	2012	Cheyenne	Body	Passenger Door Switch																																																										
K	2012	Cheyenne	Body	Passenger Presence System																																																										
K	2012	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2012	Cheyenne	Body	Theft Deterrent Module																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																																
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2012	Suburban	Chassis	Electronic Suspension Control																																																										
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Suburban	Body	Amplifier (Bose)																																																										
K	2012	Suburban	Body	Assist Step Controller																																																										
K	2012	Suburban	Body	Body Control Module																																																										
K	2012	Suburban	Body	Body Control Module (aux.)																																																										
K	2012	Suburban	Body	Digital Radio Receiver																																																										
K	2012	Suburban	Body	Driver Door Switch																																																										
K	2012	Suburban	Body	HVAC Control Module Auto									V																																																
K	2012	Suburban	Body	HVAC Control Module Manual																																																										
K	2012	Suburban	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2012	Suburban	Body	Left Side Object Detection Module																																																								
K	2012	Suburban	Body	Lift Gate Module																																																								
K	2012	Suburban	Body	Memory Seat Module																																																								
K	2012	Suburban	Body	Navigation Radio																																																								
K	2012	Suburban	Body	Park Assist Module																																																								
K	2012	Suburban	Body	Passenger Door Switch																																																								
K	2012	Suburban	Body	Passenger Presence System																																																								
K	2012	Suburban	Body	Radio																																																								
K	2012	Suburban	Body	Rear Heated Seat Module																																																								
K	2012	Suburban	Body	Rear HVAC/RSA																																																								
K	2012	Suburban	Body	Right Side Object Detection Module																																																								
K	2012	Suburban	Body	Supplemental Inflatable Restraint																																																								
K	2012	Suburban	Body	Theft Deterrent Module																																																								
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																						V																		
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																						V																		
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																													
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																													
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																								
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																								
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module											V																																												
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																												
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																								
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2012	Silverado	Chassis	Electronic Suspension Control																																																								
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																								
K	2012	Silverado	Body	Amplifier (Bose)																																																								
K	2012	Silverado	Body	Body Control Module																																																								
K	2012	Silverado	Body	Body Control Module (aux.)																																																								
K	2012	Silverado	Body	Digital Radio Receiver																																																								
K	2012	Silverado	Body	Driver Door Switch																																																								
K	2012	Silverado	Body	HVAC Control Module Auto									V																																															
K	2012	Silverado	Body	HVAC Control Module Manual									V																																															
K	2012	Silverado	Body	Instrument Panel Cluster																																																								
K	2012	Silverado	Body	Memory Seat Module																																																								
K	2012	Silverado	Body	Navigation Radio																																																								
K	2012	Silverado	Body	Park Assist Module																																																								
K	2012	Silverado	Body	Passenger Door Switch																																																								
K	2012	Silverado	Body	Passenger Presence System																																																								
K	2012	Silverado	Body	Radio																																																								
K	2012	Silverado	Body	Rear Heated Seat Module																																																								
K	2012	Silverado	Body	Rear HVAC/RSA																																																								
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																																								
K	2012	Silverado	Body	Theft Deterrent Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																								
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																								
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																								
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																								
K	2012	Silverado Hybrid	Body	Body Control Module																																																								
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																								
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																								
K	2012	Silverado Hybrid	Body	Driver Door Switch																																																								
K	2012	Silverado Hybrid	Body	Heated Seat Module																																																								
K	2012	Silverado Hybrid	Body	HVAC Control Module																																																								
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																								
K	2012	Silverado Hybrid	Body	Navigation Radio																																																								
K	2012	Silverado Hybrid	Body	Park Assist Module																																																								
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																																								
K	2012	Silverado Hybrid	Body	Passenger Presence System																																																								
K	2012	Silverado Hybrid	Body	Radio																																																								
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																									
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																									
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																									
K	2012	Tahoe	Chassis	EBCM with Trailer Brake																																																									
K	2012	Tahoe	Chassis	Electronic Suspension Control																																																									
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Tahoe	Body	Amplifier (Bose)																																																									
K	2012	Tahoe	Body	Assist Step Controller																																																									
K	2012	Tahoe	Body	Body Control Module																																																									
K	2012	Tahoe	Body	Body Control Module (aux.)																																																									
K	2012	Tahoe	Body	Digital Radio Receiver																																																									
K	2012	Tahoe	Body	Driver Door Switch																																																									
K	2012	Tahoe	Body	HVAC Control Module Auto									V																																																
K	2012	Tahoe	Body	HVAC Control Module Manual																																																									
K	2012	Tahoe	Body	Instrument Panel Cluster																																																									
K	2012	Tahoe	Body	Left Side Object Detection Module																																																									
K	2012	Tahoe	Body	Lift Gate Module																																																									
K	2012	Tahoe	Body	Memory Seat Module																																																									
K	2012	Tahoe	Body	Navigation Radio																																																									
K	2012	Tahoe	Body	Park Assist Module																																																									
K	2012	Tahoe	Body	Passenger Door Switch																																																									
K	2012	Tahoe	Body	Passenger Presence System																																																									
K	2012	Tahoe	Body	Radio																																																									
K	2012	Tahoe	Body	Rear Heated Seat Module																																																									
K	2012	Tahoe	Body	Rear HVAC/RSA																																																									
K	2012	Tahoe	Body	Right Side Object Detection Module																																																									
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																									
K	2012	Tahoe	Body	Theft Deterrent Module																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																				
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
K	2012	Tahoe Hybrid	Body	Body Control Module																																																									
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																									
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																									
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																																									
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2012	Tahoe Hybrid	Body	HVAC Control Module																																																								
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																								
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																								
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																																								
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																								
K	2012	Tahoe Hybrid	Body	Park Assist Module																																																								
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																								
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																																								
K	2012	Tahoe Hybrid	Body	Radio																																																								
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																								
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																								
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																								
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																								
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																														
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2013	Avalanche	Chassis	Electronic Brake Control Module																																																								
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																								
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Avalanche	Body	Amplifier (Bose)																																																								
K	2013	Avalanche	Body	Assist Step Controller																																																								
K	2013	Avalanche	Body	Body Control Module																																																								
K	2013	Avalanche	Body	Body Control Module (aux.)																																																								
K	2013	Avalanche	Body	Digital Radio Receiver																																																								
K	2013	Avalanche	Body	Driver Door Switch																																																								
K	2013	Avalanche	Body	HVAC Control Module Auto									V																																															
K	2013	Avalanche	Body	HVAC Control Module Manual																																																								
K	2013	Avalanche	Body	Instrument Panel Cluster																																																								
K	2013	Avalanche	Body	Memory Seat Module																																																								
K	2013	Avalanche	Body	Navigation Radio																																																								
K	2013	Avalanche	Body	Park Assist Module																																																								
K	2013	Avalanche	Body	Passenger Door Switch																																																								
K	2013	Avalanche	Body	Passenger Presence System																																																								
K	2013	Avalanche	Body	Radio																																																								
K	2013	Avalanche	Body	Rear Heated Seat Module																																																								
K	2013	Avalanche	Body	Rear HVAC/RSA																																																								
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																								
K	2013	Avalanche	Body	Theft Deterrent Module																																																								
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																					V																			
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																					V																			
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																															
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Cheyenne	Body	Amplifier (Bose)																																																										
K	2013	Cheyenne	Body	Body Control Module																																																										
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2013	Cheyenne	Body	Digital Radio Receiver																																																										
K	2013	Cheyenne	Body	Driver Door Switch																																																										
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2013	Cheyenne	Body	Park Assist Module																																																										
K	2013	Cheyenne	Body	Passenger Door Switch																																																										
K	2013	Cheyenne	Body	Passenger Presence System																																																										
K	2013	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2013	Cheyenne	Body	Theft Deterrent Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																																
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																										
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2013	Suburban	Chassis	Electronic Suspension Control																																																										
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Suburban	Body	Amplifier (Bose)																																																										
K	2013	Suburban	Body	Assist Step Controller																																																										
K	2013	Suburban	Body	Body Control Module																																																										
K	2013	Suburban	Body	Body Control Module (aux.)																																																										
K	2013	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2013	Suburban	Body	Driver Door Switch																																																								
K	2013	Suburban	Body	HVAC Control Module Auto									V																																																
K	2013	Suburban	Body	HVAC Control Module Manual																																																										
K	2013	Suburban	Body	Instrument Panel Cluster																																																										
K	2013	Suburban	Body	Left Side Object Detection Module																																																										
K	2013	Suburban	Body	Lift Gate Module																																																										
K	2013	Suburban	Body	Memory Seat Module																																																										
K	2013	Suburban	Body	Navigation Radio																																																										
K	2013	Suburban	Body	Park Assist Module																																																										
K	2013	Suburban	Body	Passenger Door Switch																																																										
K	2013	Suburban	Body	Passenger Presence System																																																										
K	2013	Suburban	Body	Radio																																																										
K	2013	Suburban	Body	Rear Heated Seat Module																																																										
K	2013	Suburban	Body	Rear HVAC/RSA																																																										
K	2013	Suburban	Body	Right Side Object Detection Module																																																										
K	2013	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2013	Suburban	Body	Theft Deterrent Module																																																										
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																						V																				
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																						V																				
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																															
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																										
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module											V																																														
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																									
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
K	2013	Silverado	Chassis	Electronic Suspension Control																																																									
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																									
K	2013	Silverado	Body	Amplifier (Bose)																																																									
K	2013	Silverado	Body	Body Control Module																																																									
K	2013	Silverado	Body	Body Control Module (aux.)																																																									
K	2013	Silverado	Body	Digital Radio Receiver																																																									
K	2013	Silverado	Body	Driver Door Switch																																																									
K	2013	Silverado	Body	HVAC Control Module Auto									V																																															
K	2013	Silverado	Body	HVAC Control Module Manual									V																																															
K	2013	Silverado	Body	Instrument Panel Cluster																																																									
K	2013	Silverado	Body	Memory Seat Module																																																									
K	2013	Silverado	Body	Navigation Radio																																																									
K	2013	Silverado	Body	Park Assist Module																																																									
K	2013	Silverado	Body	Passenger Door Switch																																																									
K	2013	Silverado	Body	Passenger Presence System																																																									
K	2013	Silverado	Body	Radio																																																									
K	2013	Silverado	Body	Rear Heated Seat Module																																																									
K	2013	Silverado	Body	Rear HVAC/RSA																																																									
K	2013	Silverado	Body	Supplemental Inflatable Restraint																																																									
K	2013	Silverado	Body	Theft Deterrent Module																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																				
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																									
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																									
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																									
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																									
K	2013	Silverado Hybrid	Body	Body Control Module																																																									
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																									
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																									
K	2013	Silverado Hybrid	Body	Driver Door Switch																																																									
K	2013	Silverado Hybrid	Body	Heated Seat Module																																																									
K	2013	Silverado Hybrid	Body	HVAC Control Module																																																									
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																									
K	2013	Silverado Hybrid	Body	Navigation Radio																																																									
K	2013	Silverado Hybrid	Body	Park Assist Module																																																									
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																																									
K	2013	Silverado Hybrid	Body	Passenger Presence System																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2013	Silverado Hybrid	Body	Radio																																																								
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																								
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																								
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																								
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2013	Tahoe	Chassis	Electronic Brake Control Module																																																								
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																								
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Tahoe	Body	Amplifier (Bose)																																																								
K	2013	Tahoe	Body	Assist Step Controller																																																								
K	2013	Tahoe	Body	Body Control Module																																																								
K	2013	Tahoe	Body	Body Control Module (aux.)																																																								
K	2013	Tahoe	Body	Digital Radio Receiver																																																								
K	2013	Tahoe	Body	Driver Door Switch																																																								
K	2013	Tahoe	Body	HVAC Control Module Auto									V																																															
K	2013	Tahoe	Body	HVAC Control Module Manual																																																								
K	2013	Tahoe	Body	Instrument Panel Cluster																																																								
K	2013	Tahoe	Body	Left Side Object Detection Module																																																								
K	2013	Tahoe	Body	Lift Gate Module																																																								
K	2013	Tahoe	Body	Memory Seat Module																																																								
K	2013	Tahoe	Body	Navigation Radio																																																								
K	2013	Tahoe	Body	Park Assist Module																																																								
K	2013	Tahoe	Body	Passenger Door Switch																																																								
K	2013	Tahoe	Body	Passenger Presence System																																																								
K	2013	Tahoe	Body	Radio																																																								
K	2013	Tahoe	Body	Rear Heated Seat Module																																																								
K	2013	Tahoe	Body	Rear HVAC/RSA																																																								
K	2013	Tahoe	Body	Right Side Object Detection Module																																																								
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																								
K	2013	Tahoe	Body	Theft Deterrent Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																								
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																								
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2013	Tahoe Hybrid	Body	Body Control Module																																																										
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																																										
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																										
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2013	Tahoe Hybrid	Body	Radio																																																										
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																										
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																										
K	2014	Cheyenne	Chassis	Power Steering Control Module																																																										
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Cheyenne	Body	Body Control Module																																																										
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Cheyenne	Body	Passenger Presence Module																																																										
K	2014	Cheyenne	Body	Instrument Cluster																																																										
K	2014	Cheyenne	Body	Radio Control																																																										
K	2014	Cheyenne	Body	HVAC Control																																																										
K	2014	Cheyenne	Body	Radio																																																										
K	2014	Cheyenne	Body	Amplifier																																																										
K	2014	Cheyenne	Body	Media Disc Player																																																										
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																										
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2014	Cheyenne	Body	HVAC Control Module																																																									
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																										
K	2014	Cheyenne	Body	Parking Assist Control Module																																																										
K	2014	Cheyenne	Body	Frontview Camera Module																																																										
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2014	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2014	Silverado	Chassis	Parking Brake Control Module																																																										
K	2014	Silverado	Chassis	Power Steering Control Module																																																										
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Silverado	Body	Body Control Module																																																										
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Silverado	Body	Passenger Presence Module																																																										
K	2014	Silverado	Body	Instrument Cluster																																																										
K	2014	Silverado	Body	Radio Control																																																										
K	2014	Silverado	Body	HVAC Control																																																										
K	2014	Silverado	Body	Radio																																																										
K	2014	Silverado	Body	Amplifier																																																										
K	2014	Silverado	Body	Media Disc Player																																																										
K	2014	Silverado	Body	Human Machine Interface Control Module																																																										
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2014	Silverado	Body	Parking Assist Control Module																																																										
K	2014	Silverado	Body	Frontview Camera Module																																																										
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																										
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																										
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2014	Silverado HD	Chassis	Suspension Control Module																																																								
K	2014	Silverado HD	Body	Body Control Module																																																								
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2014	Silverado HD	Body	Passenger Presence Module																																																								
K	2014	Silverado HD	Body	Instrument Cluster																																																								
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																								
K	2014	Silverado HD	Body	Base Radio																																																								
K	2014	Silverado HD	Body	Navigation Radio																																																								
K	2014	Silverado HD	Body	Uplevel Radio																																																								
K	2014	Silverado HD	Body	Amplifier																																																								
K	2014	Silverado HD	Body	Rear Audio Control Module																																																								
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																								
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																V									
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																								
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																								
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																								
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																								
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																								
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																								
K	2014	Silverado HD	Body	Seat Memory Control Module																																																								
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																								
K	2014	Silverado HD	Body	Parking Assist Control Module																																																								
K	2014	Silverado HD	Body	Theft Deterrent Module																																																								
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																								
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																								
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																								
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																								
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																								
K	2014	Suburban	Chassis	Parking Brake Control Module																																																								
K	2014	Suburban	Chassis	Suspension Control Module																																																								
K	2014	Suburban	Body	Body Control Module																																																								
K	2014	Suburban	Body	Auxiliary Body Control Module																																																								
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2014	Suburban	Body	Passenger Presence Module																																																								
K	2014	Suburban	Body	Instrument Cluster																																																								
K	2014	Suburban	Body	Base Radio																																																								
K	2014	Suburban	Body	Navigation Radio																																																								
K	2014	Suburban	Body	Uplevel Radio																																																								
K	2014	Suburban	Body	Amplifier																																																								
K	2014	Suburban	Body	Rear Audio Control Module																																																								
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																								
K	2014	Suburban	Body	Personal Audio Link Control Module																																																V									
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																								
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																									
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																									
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																									
K	2014	Suburban	Body	Liftgate Control Module																																																									
K	2014	Suburban	Body	Seat Memory Control Module																																																									
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																									
K	2014	Suburban	Body	Assist Step Control Module																																																									
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																									
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																									
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																									
K	2014	Suburban	Body	Parking Assist Control Module																																																									
K	2014	Suburban	Body	Theft Deterrent Module																																																									
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																									
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																									
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																									
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																									
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																									
K	2014	Tahoe	Chassis	Suspension Control Module																																																									
K	2014	Tahoe	Body	Body Control Module																																																									
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																									
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2014	Tahoe	Body	Passenger Presence Module																																																									
K	2014	Tahoe	Body	Instrument Cluster																																																									
K	2014	Tahoe	Body	Base Radio																																																									
K	2014	Tahoe	Body	Navigation Radio																																																									
K	2014	Tahoe	Body	Uplevel Radio																																																									
K	2014	Tahoe	Body	Amplifier																																																									
K	2014	Tahoe	Body	Rear Audio Control Module																																																									
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																									
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																									
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																									
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																									
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																									
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																									
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																									
K	2014	Tahoe	Body	Liftgate Control Module																																																									
K	2014	Tahoe	Body	Seat Memory Control Module																																																									
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																									
K	2014	Tahoe	Body	Assist Step Control Module																																																									
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																									
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																									
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																									
K	2014	Tahoe	Body	Parking Assist Control Module																																																									
K	2014	Tahoe	Body	Theft Deterrent Module																																																									
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																									
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																									
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																									
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																									
K	2015	Cheyenne	Chassis	Power Steering Control Module																																																									
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2015	Cheyenne	Chassis	Suspension Control Module																																																									
K	2015	Cheyenne	Body	Body Control Module																																																									
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2015	Cheyenne	Body	Passenger Presence Module																																																									
K	2015	Cheyenne	Body	Instrument Cluster																																																									
K	2015	Cheyenne	Body	Radio Controls																																																									
K	2015	Cheyenne	Body	HVAC Controls																																																									
K	2015	Cheyenne	Body	Radio																																																									
K	2015	Cheyenne	Body	Amplifier																																																									
K	2015	Cheyenne	Body	Media Disc Player																																																									
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																									
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																									
K	2015	Cheyenne	Body	HVAC Control Module																																																									
K	2015	Cheyenne	Body	Parking Assist Control Module																																																									
K	2015	Cheyenne	Body	Frontview Camera Module																																																									
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																									
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																									
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																									
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																									
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																									
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2015	Silverado	Chassis	Electronic Brake Control Module																																																									
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																									
K	2015	Silverado	Chassis	Power Steering Control Module																																																									
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2015	Silverado	Chassis	Suspension Control Module																																																									
K	2015	Silverado	Body	Body Control Module																																																									
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2015	Silverado	Body	Passenger Presence Module																																																									
K	2015	Silverado	Body	Instrument Cluster																																																									
K	2015	Silverado	Body	Radio Controls																																																									
K	2015	Silverado	Body	HVAC Controls																																																									
K	2015	Silverado	Body	Radio																																																									
K	2015	Silverado	Body	Amplifier																																																									
K	2015	Silverado	Body	Media Disc Player																																																									
K	2015	Silverado	Body	Human Machine Interface Control Module																																																									
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																																									
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																									
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																									
K	2015	Silverado	Body	Parking Assist Control Module																																																									
K	2015	Silverado	Body	Frontview Camera Module																																																									
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																									
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																									
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2015	Suburban	Chassis	Electronic Brake Control Module																																																									
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																									
K	2015	Suburban	Chassis	Parking Brake Control Module																																																									
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																									
K	2015	Suburban	Chassis	Power Steering Control Module																																																									
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2015	Suburban	Chassis	Suspension Control Module																																																									
K	2015	Suburban	Body	Body Control Module																																																									
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2015	Suburban	Body	Passenger Presence Module																																																									
K	2015	Suburban	Body	Instrument Cluster																																																									
K	2015	Suburban	Body	Radio Controls																																																									
K	2015	Suburban	Body	HVAC Controls																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2015	Suburban	Body	Radio																																																								
K	2015	Suburban	Body	Amplifier																																																								
K	2015	Suburban	Body	Media Disc Player																																																								
K	2015	Suburban	Body	Human Machine Interface Control Module																																																								
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																								
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																								
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																								
K	2015	Suburban	Body	HVAC Control Module																																																								
K	2015	Suburban	Body	Liftgate Control Module																																																								
K	2015	Suburban	Body	Keyless Entry Control Module																																																								
K	2015	Suburban	Body	Assist Step Control Module																																																								
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																								
K	2015	Suburban	Body	Parking Assist Control Module																																																								
K	2015	Suburban	Body	Frontview Camera Module																																																								
K	2015	Suburban	Body	Steering Column Lock Control Module																																																								
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																								
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																								
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																								
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																								
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																								
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																																								
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																								
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																								
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																								
K	2015	Tahoe	Chassis	Power Steering Control Module																																																								
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2015	Tahoe	Chassis	Suspension Control Module																																																								
K	2015	Tahoe	Body	Body Control Module																																																								
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2015	Tahoe	Body	Passenger Presence Module																																																								
K	2015	Tahoe	Body	Instrument Cluster																																																								
K	2015	Tahoe	Body	Radio Controls																																																								
K	2015	Tahoe	Body	HVAC Controls																																																								
K	2015	Tahoe	Body	Radio																																																								
K	2015	Tahoe	Body	Amplifier																																																								
K	2015	Tahoe	Body	Media Disc Player																																																								
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																								
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																								
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																								
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																								
K	2015	Tahoe	Body	HVAC Control Module																																																								
K	2015	Tahoe	Body	Liftgate Control Module																																																								
K	2015	Tahoe	Body	Keyless Entry Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2015	Tahoe	Body	Assist Step Control Module																																																								
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																									
K	2015	Tahoe	Body	Parking Assist Control Module																																																									
K	2015	Tahoe	Body	Frontview Camera Module																																																									
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																									
K	2015	Tahoe	Body	Battery Energy Control Module																																																									
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																									
K	2016	Cheyenne	Chassis	Power Steering Control Module																																																									
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																									
K	2016	Cheyenne	Chassis	Suspension Control Module																																																									
K	2016	Cheyenne	Body	Body Control Module																																																									
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
K	2016	Cheyenne	Body	Passenger Presence Module																																																									
K	2016	Cheyenne	Body	Instrument Cluster																																																									
K	2016	Cheyenne	Body	Radio Controls																																																									
K	2016	Cheyenne	Body	HVAC Controls																																																									
K	2016	Cheyenne	Body	Radio																																																									
K	2016	Cheyenne	Body	Amplifier																																																									
K	2016	Cheyenne	Body	Media Disc Player																																																									
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																									
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																									
K	2016	Cheyenne	Body	HVAC Control Module																																																									
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																									
K	2016	Cheyenne	Body	Parking Assist Control Module																																																									
K	2016	Cheyenne	Body	Frontview Camera Module																																																									
K	2016	Cheyenne	Body	Frontview Camera Module																																																									
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																									
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2016	Silverado	Chassis	Power Steering Control Module																																																										
K	2016	Silverado	Chassis	Power Steering Control Module																																																										
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Silverado	Chassis	Suspension Control Module																																																										
K	2016	Silverado	Body	Body Control Module																																																										
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Silverado	Body	Passenger Presence Module																																																										
K	2016	Silverado	Body	Instrument Cluster																																																										
K	2016	Silverado	Body	Radio Controls																																																									
K	2016	Silverado	Body	HVAC Controls																																																									
K	2016	Silverado	Body	Radio (IO3)																																																									
K	2016	Silverado	Body	Radio (IOB)																																																									
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																									
K	2016	Silverado	Body	Amplifier																																																									
K	2016	Silverado	Body	Media Disc Player																																																									
K	2016	Silverado	Body	Human Machine Interface Control Module																																																										
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																										
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																										
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																										
K	2016	Silverado	Body	Parking Assist Control Module																																																										
K	2016	Silverado	Body	Frontview Camera Module																																																										
K	2016	Silverado	Body	Frontview Camera Module																																																										
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
K	2016	Suburban	Chassis	Parking Brake Control Module																																																										
K	2016	Suburban	Chassis	Power Steering Control Module																																																										
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Suburban	Chassis	Suspension Control Module																																																										
K	2016	Suburban	Body	Body Control Module																																																										
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2016	Suburban	Body	Passenger Presence Module																																																								
K	2016	Suburban	Body	Instrument Cluster																																																								
K	2016	Suburban	Body	Radio Controls																																																								
K	2016	Suburban	Body	HVAC Controls																																																								
K	2016	Suburban	Body	Radio																																																								
K	2016	Suburban	Body	Amplifier																																																								
K	2016	Suburban	Body	Media Disc Player																																																								
K	2016	Suburban	Body	Human Machine Interface Control Module																																																								
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																																								
K	2016	Suburban	Body	HVAC Control Module																																																								
K	2016	Suburban	Body	Liftgate Control Module																																																		V						
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																								
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																								
K	2016	Suburban	Body	Keyless Entry Control Module																																																								
K	2016	Suburban	Body	Assist Step Control Module																																																								
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																								
K	2016	Suburban	Body	Parking Assist Control Module																																																								
K	2016	Suburban	Body	Frontview Camera Module																																																								
K	2016	Suburban	Body	Steering Column Lock Control Module																																																								
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																																								
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																								
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																								
K	2016	Tahoe	Chassis	Power Steering Control Module																																																								
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																								
K	2016	Tahoe	Chassis	Suspension Control Module																																																								
K	2016	Tahoe	Body	Body Control Module																																																								
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
K	2016	Tahoe	Body	Passenger Presence Module																																																								
K	2016	Tahoe	Body	Instrument Cluster																																																								
K	2016	Tahoe	Body	Radio Controls																																																								
K	2016	Tahoe	Body	HVAC Controls																																																								
K	2016	Tahoe	Body	Radio																																																								
K	2016	Tahoe	Body	Amplifier																																																								
K	2016	Tahoe	Body	Media Disc Player																																																								
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																								
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																								
K	2016	Tahoe	Body	HVAC Control Module																																																								
K	2016	Tahoe	Body	Liftgate Control Module																																																		V						
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																								
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																								
K	2016	Tahoe	Body	Keyless Entry Control Module																																																								
K	2016	Tahoe	Body	Assist Step Control Module																																																								
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																								
K	2016	Tahoe	Body	Parking Assist Control Module																																																								
K	2016	Tahoe	Body	Frontview Camera Module																																																								
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																								
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																					
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
L	2004	ALL	Chassis	4WAL 3 Sensor																																																									
L	2004	ALL	Body	Body Control Module																																																								
L	2004	ALL	Body	Instrument Panel Cluster																																																								
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
L	2005	Astro	Chassis	4WAL 3 Sensor																																																								
L	2005	Astro	Body	Body Control Module																																																								
L	2005	Astro	Body	Instrument Panel Cluster																																																								
L	2005	Astro	Body	Supplemental Inflatable Restraint																																																								
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																								
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																								
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																																								
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																																								
L	2005	Equinox	Chassis	Electric Power Steering																																																								
L	2005	Equinox	Body	Body Control Module																																																								
L	2005	Equinox	Body	Instrument Panel Cluster																																																								
L	2005	Equinox	Body	Radio	V	V																																																						
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																																								
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																								
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																								
L	2006	ALL	Chassis	Traction Control Yes																																																								
L	2006	ALL	Chassis	Traction Control No																																																								
L	2006	ALL	Chassis	Electric Power Steering																																																								
L	2006	ALL	Body	Body Control Module																																																								
L	2006	ALL	Body	Instrument Panel Cluster																																																								
L	2006	ALL	Body	Radio	V	V																																																						
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																								
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																								
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																								
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																																								
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																																								
L	2007	ALL	Chassis	Power Steering Control Module																																																								
L	2007	ALL	Body	Body Control Module																																																								
L	2007	ALL	Body	Digital Radio Receiver																																																								
L	2007	ALL	Body	Heated Seat Module																																																								
L	2007	ALL	Body	HVAC Control Module																																																								
L	2007	ALL	Body	Instrument Panel Cluster																																																								
L	2007	ALL	Body	Passenger Presence System																																																								
L	2007	ALL	Body	Radio																																																								
L	2007	ALL	Body	Rollover Sensor																																																								
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2007	ALL	Body	Theft Deterrent Module																																																								
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																								
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																								
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																V					V																			
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																																								
L	2008	Captiva Sport	Body	Body Control Module																																																								
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																								
L	2008	Captiva Sport	Body	HVAC Control Module Auto																																																								
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																																								
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																																								
L	2008	Captiva Sport	Body	Passenger Presence System																																																								
L	2008	Captiva Sport	Body	Radio																																																								
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																																								
L	2008	Captiva Sport	Body	Rollover Sensor																																																								
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																																								
L	2008	Captiva Sport	Body	Theft Deterrent Module																																																								
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																								
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																								
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																								
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																								
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
L	2008	Equinox	Chassis	Electronic Brake Control Module																																																								
L	2008	Equinox	Chassis	Power Steering Control Module																																																								
L	2008	Equinox	Body	Body Control Module																																																								
L	2008	Equinox	Body	Digital Radio Receiver																																																								
L	2008	Equinox	Body	Heated Seat Module																																																								
L	2008	Equinox	Body	HVAC Control Module																																																								
L	2008	Equinox	Body	Instrument Panel Cluster																																																								
L	2008	Equinox	Body	Passenger Presence System																																																								
L	2008	Equinox	Body	Radio																																																								
L	2008	Equinox	Body	Rollover Sensor																																																								
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																																								
L	2008	Equinox	Body	Theft Deterrent Module																																																								
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																								
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																								
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																								
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																								
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																															V				V		V																			
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																								
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																																								
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																								
L	2009	Captiva Sport	Body	Body Control Module																																																								
L	2009	Captiva Sport	Body	HVAC Control Module Auto																																																								
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																																								
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																																								
L	2009	Captiva Sport	Body	Passenger Presence System																																																								
L	2009	Captiva Sport	Body	Radio																																																								
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																																								
L	2009	Captiva Sport	Body	Rollover Sensor																																																								
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																																								
L	2009	Captiva Sport	Body	Theft Deterrent Module																																																								
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																								
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																								
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																								
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																								
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
L	2009	Equinox	Chassis	Electronic Brake Control Module																																																								
L	2009	Equinox	Chassis	Power Steering Control Module																																																								
L	2009	Equinox	Body	Body Control Module																																																								
L	2009	Equinox	Body	Digital Radio Receiver																																																								
L	2009	Equinox	Body	Heated Seat Module																																																								
L	2009	Equinox	Body	HVAC Control Module																																																								
L	2009	Equinox	Body	Instrument Panel Cluster																																																								
L	2009	Equinox	Body	Passenger Presence System																																																								
L	2009	Equinox	Body	Radio																																																								
L	2009	Equinox	Body	Rollover Sensor																																																								
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																																								
L	2009	Equinox	Body	Theft Deterrent Module																																																								
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																								
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																								
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																								
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																								
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																								
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																								
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																															V					V		V																		
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																								
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																								
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																								
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																																								
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																								
L	2010	Captiva Sport	Body	Body Control Module																																																								
L	2010	Captiva Sport	Body	HVAC Control Module																																																								
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																																								
L	2010	Captiva Sport	Body	Passenger Presence System																																																								
L	2010	Captiva Sport	Body	Radio																																																								
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																																								
L	2010	Captiva Sport	Body	Rollover Sensor																																																								
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																																								
L	2010	Captiva Sport	Body	Theft Deterrent Module																																																								
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																								
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																								
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																								
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																								
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																								
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																								
L	2010	Equinox	Chassis	Electronic Brake Control Module																																																								
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2010	Equinox	Body	Body Control Module																																																								
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2010	Equinox	Body	Passenger Presence Module																																																								
L	2010	Equinox	Body	Instrument Cluster																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2010	Equinox	Body	Radio																																																								
L	2010	Equinox	Body	Multimedia Player Interface Module																																																								
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																																								
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																																								
L	2010	Equinox	Body	Liftgate Control Module																																																								
L	2010	Equinox	Body	Parking Assist Control Module																																																								
L	2010	Equinox	Body	Frontview Camera Module																																																								
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																																								
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																								
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																								
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																								
L	2011	Captiva	Chassis	Electronic Brake Control Module																																																								
L	2011	Captiva	Chassis	Parking Brake Control Module																																																								
L	2011	Captiva	Body	Body Control Module																																																								
L	2011	Captiva	Body	Auxiliary Body Control Module																																																								
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2011	Captiva	Body	Instrument Cluster																																																								
L	2011	Captiva	Body	Headlamp Control Module																																																								
L	2011	Captiva	Body	HVAC Control Module																																																								
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																								
L	2011	Captiva	Body	Parking Assist Control Module																																																								
L	2011	Captiva	Body	Theft Deterrent Module																																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module																																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module																																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module																																																									
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																																										
L	2011	Captiva Sport	Body	Body Control Module																																																										
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2011	Captiva Sport	Body	HVAC Control Module																																																										
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2011	Captiva Sport	Body	Passenger Presence System																																																										
L	2011	Captiva Sport	Body	Radio																																																										
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2011	Captiva Sport	Body	Rollover Sensor																																																										
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2011	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																																										
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																										
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																										
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2011	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2011	Equinox	Body	Body Control Module																																																										
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2011	Equinox	Body	Passenger Presence Module																																																										
L	2011	Equinox	Body	Instrument Cluster																																																										
L	2011	Equinox	Body	Radio																																																										
L	2011	Equinox	Body	Multimedia Player Interface Module																																																										
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2011	Equinox	Body	Liftgate Control Module																																																										
L	2011	Equinox	Body	Parking Assist Control Module																																																										
L	2011	Equinox	Body	Frontview Camera Module																																																										
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																																																										
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																										
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																								
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																									
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																									
L	2012	Captiva	Chassis	Electronic Brake Control Module																																																									
L	2012	Captiva	Chassis	Parking Brake Control Module																																																									
L	2012	Captiva	Body	Body Control Module																																																									
L	2012	Captiva	Body	Auxiliary Body Control Module																																																									
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2012	Captiva	Body	Instrument Cluster																																																									
L	2012	Captiva	Body	Headlamp Control Module																																																									
L	2012	Captiva	Body	HVAC Control Module																																																									
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																									
L	2012	Captiva	Body	Parking Assist Control Module																																																									
L	2012	Captiva	Body	Theft Deterrent Module																																																									
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																									
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																									
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																									
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																									
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																									
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																									
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																									
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																									
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module																																																									
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																																									
L	2012	Captiva Sport	Body	Body Control Module																																																									
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																									
L	2012	Captiva Sport	Body	HVAC Control Module																																																									
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																																									
L	2012	Captiva Sport	Body	Passenger Presence System																																																									
L	2012	Captiva Sport	Body	Radio																																																									
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																																									
L	2012	Captiva Sport	Body	Rollover Sensor																																																									
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																																																									
L	2012	Captiva Sport	Body	Theft Deterrent Module																																																									
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																									
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																									
L	2012	Equinox	Chassis	Electronic Brake Control Module																																																									
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2012	Equinox	Body	Body Control Module																																																								
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2012	Equinox	Body	Passenger Presence Module																																																									
L	2012	Equinox	Body	Instrument Cluster																																																									
L	2012	Equinox	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2012	Equinox	Body	Multimedia Player Interface Module																																																								
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																								
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																								
L	2012	Equinox	Body	Liftgate Control Module																																																								
L	2012	Equinox	Body	Parking Assist Control Module																																																								
L	2012	Equinox	Body	Frontview Camera Module																																																								
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																																								
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																								
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																								
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																								
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																								
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																								
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																								
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																								
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																								
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																								
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																								
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																								
L	2013	Captiva	Chassis	Parking Brake Control Module																																																								
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																								
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																								
L	2013	Captiva	Body	Auxiliary Body Control Module																																																								
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2013	Captiva	Body	Instrument Cluster																																																								
L	2013	Captiva	Body	Headlamp Control Module																																																								
L	2013	Captiva	Body	HVAC Control Module																																																								
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																								
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																								
L	2013	Captiva	Body	Theft Deterrent Module																																																								
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																								
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																								
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																								
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																								
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																								
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																								
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																																								
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																								
L	2013	Captiva Sport	Body	Body Control Module																																																								
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																								
L	2013	Captiva Sport	Body	Heated Seat Module																																																								
L	2013	Captiva Sport	Body	HVAC Control Module																																																								
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2013	Captiva Sport	Body	Park Assist Module																																																								
L	2013	Captiva Sport	Body	Passenger Presence System																																																								
L	2013	Captiva Sport	Body	Radio																																																								
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																								
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																																								
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																								
L	2013	Captiva Sport	Body	Theft Deterrent Module																																																								
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																								
L	2013	Equinox	Chassis	Electronic Brake Control Module																																																								
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2013	Equinox	Chassis	Power Steering Control Module																																																								
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																								
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																								
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2013	Equinox	Body	Passenger Presence Module																																																								
L	2013	Equinox	Body	Instrument Cluster																																																								
L	2013	Equinox	Body	Radio																																																								
L	2013	Equinox	Body	Rear Audio Control Module																																																								
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																								
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																								
L	2013	Equinox	Body	Liftgate Control Module																																																								
L	2013	Equinox	Body	Front Seat Heating Control Module																																																								
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																								
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																								
L	2013	Equinox	Body	Parking Assist Control Module																																																								
L	2013	Equinox	Body	Frontview Camera Module																																																								
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																								
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																								
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																								
L	2014	Captiva (3GN)	Body	Body Control Module																																																								
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																								
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																								
L	2014	Captiva (3GN)	Body	Radio																																																								
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																								
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																								
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																								
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																									
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																										
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Captiva (Other)	Body	Instrument Cluster																																																										
L	2014	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2014	Captiva (Other)	Body	HVAC Control Module																																																										
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2014	Captiva (Other)	Body	Theft Deterrent Module																																																										
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2014	Equinox	Chassis	Power Steering Control Module																																																										
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Equinox	Body	Passenger Presence Module																																																										
L	2014	Equinox	Body	Instrument Cluster																																																										
L	2014	Equinox	Body	Radio																																																										
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2014	Equinox	Body	Liftgate Control Module																																																								
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																									
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																									
L	2014	Equinox	Body	Parking Assist Control Module																																																									
L	2014	Equinox	Body	Frontview Camera Module																																																									
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																									
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																									
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																									
L	2015	Captiva (3GN)	Body	Body Control Module																																																									
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																																									
L	2015	Captiva (3GN)	Body	Instrument Cluster																																																									
L	2015	Captiva (3GN)	Body	Radio																																																									
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																									
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																									
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																									
L	2015	Captiva (3GN)	Body	HVAC Control Module																																																									
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																									
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																									
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																									
L	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																									
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																									
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																									
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																									
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																									
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																									
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																									
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																									
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																									
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																									
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																									
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																									
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																									
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																									
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2015	Captiva (Other)	Body	Instrument Cluster																																																									
L	2015	Captiva (Other)	Body	Headlamp Control Module																																																									
L	2015	Captiva (Other)	Body	HVAC Control Module																																																									
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																								
L	2015	Captiva (Other)	Body	Theft Deterrent Module																																																									
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																									
L	2015	Equinox	Chassis	Electronic Brake Control Module																																																									
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2015	Equinox	Chassis	Power Steering Control Module																																																									
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																																									
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																									
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2015	Equinox	Body	Passenger Presence Module																																																									
L	2015	Equinox	Body	Instrument Cluster																																																									
L	2015	Equinox	Body	Radio																																																									
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																																									
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																																									
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																																									
L	2015	Equinox	Body	Liftgate Control Module																																																									
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																									
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																									
L	2015	Equinox	Body	Parking Assist Control Module																																																									
L	2015	Equinox	Body	Frontview Camera Module																																																									
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																									
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																									
L	2016	Captiva (3GN)	Body	Body Control Module																																																									
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2016	Captiva (3GN)	Body	Instrument Cluster																																																									
L	2016	Captiva (3GN)	Body	Radio																																																									
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																									
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																									
L	2016	Captiva (3GN)	Body	HVAC Control Module																																																									
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																									
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																									
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																									
L	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																									
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																									
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																									
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																								
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																								
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																								
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																								
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																								
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																								
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																								
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																								
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																								
L	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																								
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																								
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																								
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																								
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2016	Captiva (Other)	Body	Instrument Cluster																																																								
L	2016	Captiva (Other)	Body	Headlamp Control Module																																																								
L	2016	Captiva (Other)	Body	Radio																																																								
L	2016	Captiva (Other)	Body	HVAC Control Module																																																								
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																								
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																								
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																								
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																								
L	2016	Captiva (Other)	Body	Theft Deterrent Module																																																								
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																																								
L	2016	Equinox	Chassis	Electronic Brake Control Module																																																								
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2016	Equinox	Chassis	Power Steering Control Module																																																								
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate																																																								
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																								
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2016	Equinox	Body	Passenger Presence Module																																																								
L	2016	Equinox	Body	Instrument Cluster																																																								
L	2016	Equinox	Body	Radio																																																								
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																																								
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																																																								
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																																																								
L	2016	Equinox	Body	Liftgate Control Module																																																								
L	2016	Equinox	Body	Seat Memory Control Module																																																								
L	2016	Equinox	Body	Right Side Object Detection Control Module																																																								
L	2016	Equinox	Body	Left Side Object Detection Control Module																																																								
L	2016	Equinox	Body	Parking Assist Control Module																																																								
L	2016	Equinox	Body	Frontview Camera Module																																																								
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																					V																																			

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
M	2004	ALL	Chassis	4WAL 3 Sensor																																																								
M	2004	ALL	Body	Body Control Module																																																								
M	2004	ALL	Body	Instrument Panel Cluster																																																								
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
M	2005	ALL	Chassis	4WAL 3 Sensor																																																								
M	2005	ALL	Body	Body Control Module																																																								
M	2005	ALL	Body	Instrument Panel Cluster																																																								
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
P	2007	ALL	Body	Theft Deterrent Module																																																								
R	2009	ALL	Powertrain	Engine Control Module																																																								
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2009	ALL	Powertrain	Transmission Control Module																																																								
R	2009	ALL	Chassis	Electronic Brake Control Module																																																								
R	2009	ALL	Body	Body Control Module																																																								
R	2009	ALL	Body	Digital Radio Receiver																																																								
R	2009	ALL	Body	Driver Door Switch																																																								
R	2009	ALL	Body	Heated Seat Module																																																								
R	2009	ALL	Body	HVAC Control Module Auto																																																								
R	2009	ALL	Body	HVAC Control Module Manual																																																								
R	2009	ALL	Body	Instrument Panel Cluster																																																								
R	2009	ALL	Body	Lift Gate Module																																																								
R	2009	ALL	Body	Park Assist Module																																																								
R	2009	ALL	Body	Passenger Door Switch																																																								
R	2009	ALL	Body	Passenger Presence System																																																								
R	2009	ALL	Body	Radio																																																								
R	2009	ALL	Body	Rear HVAC/RSA																																																								
R	2009	ALL	Body	Rollover Sensor																																																								
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2009	ALL	Body	Theft Deterrent Module																																																								
R	2010	ALL	Powertrain	Engine Control Module																																																								
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2010	ALL	Powertrain	Transmission Control Module																																																								
R	2010	ALL	Chassis	Electronic Brake Control Module																																																								
R	2010	ALL	Body	Body Control Module																																																								
R	2010	ALL	Body	Digital Radio Receiver																																																								
R	2010	ALL	Body	Driver Door Switch																																																								
R	2010	ALL	Body	Heated Seat Module																																																								
R	2010	ALL	Body	HVAC Control Module Auto									V																																															
R	2010	ALL	Body	HVAC Control Module Manual																																																								
R	2010	ALL	Body	Instrument Panel Cluster																																																								
R	2010	ALL	Body	Lift Gate Module																																																								
R	2010	ALL	Body	Park Assist Module																																																								
R	2010	ALL	Body	Passenger Door Switch																																																								
R	2010	ALL	Body	Passenger Presence System																																																								
R	2010	ALL	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2010	ALL	Body	Rear HVAC/RSA																																																								
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2010	ALL	Body	Theft Deterrent Module																																																								
R	2011	ALL	Powertrain	Engine Control Module																																																								
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2011	ALL	Powertrain	Transmission Control Module																																																								
R	2011	ALL	Chassis	Electronic Brake Control Module																																																								
R	2011	ALL	Body	Body Control Module																																																								
R	2011	ALL	Body	Digital Radio Receiver																																																								
R	2011	ALL	Body	Driver Door Switch																																																								
R	2011	ALL	Body	Heated Seat Module																																																								
R	2011	ALL	Body	HVAC Control Module Auto									V																																															
R	2011	ALL	Body	HVAC Control Module Manual																																																								
R	2011	ALL	Body	Instrument Panel Cluster																																																								
R	2011	ALL	Body	Lift Gate Module																																																								
R	2011	ALL	Body	Park Assist Module																																																								
R	2011	ALL	Body	Passenger Door Switch																																																								
R	2011	ALL	Body	Passenger Presence System																																																								
R	2011	ALL	Body	Radio																																																								
R	2011	ALL	Body	Rear HVAC/RSA																																																								
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2011	ALL	Body	Theft Deterrent Module																																																								
R	2012	ALL	Powertrain	Engine Control Module																																																								
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2012	ALL	Powertrain	Transmission Control Module																																																								
R	2012	ALL	Chassis	Electronic Brake Control Module																																																								
R	2012	ALL	Body	Body Control Module																																																								
R	2012	ALL	Body	Digital Radio Receiver																																																								
R	2012	ALL	Body	Driver Door Switch																																																								
R	2012	ALL	Body	Heated Seat Module																																																								
R	2012	ALL	Body	HVAC Control Module Auto									V																																															
R	2012	ALL	Body	HVAC Control Module Manual																																																								
R	2012	ALL	Body	Instrument Panel Cluster																																																								
R	2012	ALL	Body	Lift Gate Module																																																								
R	2012	ALL	Body	Park Assist Module																																																								
R	2012	ALL	Body	Passenger Door Switch																																																								
R	2012	ALL	Body	Passenger Presence System																																																								
R	2012	ALL	Body	Radio																																																								
R	2012	ALL	Body	Rear HVAC/RSA																																																								
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2012	ALL	Body	Theft Deterrent Module																																																								
R	2013	ALL	Powertrain	Engine Control Module																																																								
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2013	ALL	Powertrain	Transmission Control Module																																																								
R	2013	ALL	Chassis	Electronic Brake Control Module																																																								
R	2013	ALL	Body	Body Control Module																																																								
R	2013	ALL	Body	Digital Radio Receiver																																																								
R	2013	ALL	Body	Driver Door Switch																																																								
R	2013	ALL	Body	Heated Seat Module																																																								
R	2013	ALL	Body	HVAC Control Module Auto									V																																															
R	2013	ALL	Body	HVAC Control Module Manual																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2013	ALL	Body	Instrument Panel Cluster																																																								
R	2013	ALL	Body	Left Side Object Detection Module																																																								
R	2013	ALL	Body	Lift Gate Module																																																								
R	2013	ALL	Body	Park Assist Module																																																								
R	2013	ALL	Body	Passenger Door Switch																																																								
R	2013	ALL	Body	Passenger Presence System																																																								
R	2013	ALL	Body	Radio																																																								
R	2013	ALL	Body	Rear HVAC/RSA																																																								
R	2013	ALL	Body	Right Side Object Detection Module																																																								
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2013	ALL	Body	Theft Deterrent Module																																																								
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2014	Traverse	Powertrain	Chassis Control Module																																																								
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																								
R	2014	Traverse	Chassis	Electronic Brake Control Module																																													V											
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																								
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																								
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2014	Traverse	Body	Passenger Presence Module																																																								
R	2014	Traverse	Body	Instrument Cluster																																																								
R	2014	Traverse	Body	Radio																																																								
R	2014	Traverse	Body	Rear Audio Control Module																																																								
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																								
R	2014	Traverse	Body	Personal Audio Link Control Module																																															V										
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																								
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																								
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																								
R	2014	Traverse	Body	Liftgate Control Module																																																								
R	2014	Traverse	Body	Seat Memory Control Module																																																								
R	2014	Traverse	Body	Front Seat Heating Control Module																																																								
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																								
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																								
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																								
R	2014	Traverse	Body	Parking Assist Control Module																																																								
R	2014	Traverse	Body	Frontview Camera Module																																																								
R	2014	Traverse	Body	Theft Deterrent Module																																																								
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																								
R	2015	Traverse	Chassis	Electronic Brake Control Module																																													V										
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																								
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																								
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2015	Traverse	Body	Passenger Presence Module																																																								
R	2015	Traverse	Body	Instrument Cluster																																																								
R	2015	Traverse	Body	Radio																																																								
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																								
R	2015	Traverse	Body	Liftgate Control Module																																																								
R	2015	Traverse	Body	Seat Memory Control Module																																																								
R	2015	Traverse	Body	Front Seat Heating Control Module																																																								
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																								
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																								
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																								
R	2015	Traverse	Body	Parking Assist Control Module																																																								
R	2015	Traverse	Body	Frontview Camera Module																																																								
R	2015	Traverse	Body	Theft Deterrent Module																																																								
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																								
R	2016	Traverse	Chassis	Electronic Brake Control Module																																														V										
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																								
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																								
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2016	Traverse	Body	Passenger Presence Module																																																								
R	2016	Traverse	Body	Instrument Cluster																																																								
R	2016	Traverse	Body	Radio																																																								
R	2016	Traverse	Body	Rear Audio Control Module																																																								
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																								
R	2016	Traverse	Body	Personal Audio Link Control Module																																															V									
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																								
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																								
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																								
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																								
R	2016	Traverse	Body	Liftgate Control Module																																																								
R	2016	Traverse	Body	Seat Memory Control Module																																																								
R	2016	Traverse	Body	Front Seat Heating Control Module																																																								
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																								
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																								
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																								
R	2016	Traverse	Body	Parking Assist Control Module																																																								
R	2016	Traverse	Body	Frontview Camera Module																																																								
R	2016	Traverse	Body	Theft Deterrent Module																																																								
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																					V																																			
S	2004	S10	Chassis	4WAL 3 Sensor																																																								
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																								
S	2004	S10	Body	Body Control Module																																																								
S	2004	S10	Body	Instrument Panel Cluster																																																								
S	2004	S10	Body	Base Radio																																																								
S	2004	S10	Body	Uplevel Radio																																																								
S	2004	S10	Body	Supplemental Inflatable Restraint																																																								
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																								
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																					V																																			

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																				V																																							
S	2004	Colorado	Chassis	ABS Without Traction Control																																																											
S	2004	Colorado	Chassis	ABS With Traction Control																																																											
S	2004	Colorado	Body	Body Control Module																																																										
S	2004	Colorado	Body	Instrument Panel Cluster																																																											
S	2004	Colorado	Body	OnStar																																																										
S	2004	Colorado	Body	Base Radio																																																										
S	2004	Colorado	Body	Uplevel Radio																																																										
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																							
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																											
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																											
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																											
S	2004	TrailBlazer	Body	Body Control Module																																																											
S	2004	TrailBlazer	Body	Driver Door Module																																																											
S	2004	TrailBlazer	Body	Driver Seat Module																								V																												V							
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																								V																												V	V					
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																								V																												V	V					
S	2004	TrailBlazer	Body	Instrument Panel Cluster																V	V							V																																		
S	2004	TrailBlazer	Body	Lift Gate Module																																																											
S	2004	TrailBlazer	Body	OnStar																																																										
S	2004	TrailBlazer	Body	Passenger Door Module																																																											
S	2004	TrailBlazer	Body	Uplevel Radio																																																											
S	2004	TrailBlazer	Body	Navigation Radio																																																											
S	2004	TrailBlazer	Body	Rear Seat Audio																																																											
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																											
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																											
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																											
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																							
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																											
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																				V																																							
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																											
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																											
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																											
S	2004	TrailBlazer EXT	Body	Body Control Module																																																											
S	2004	TrailBlazer EXT	Body	Driver Door Module																																																											
S	2004	TrailBlazer EXT	Body	Driver Seat Module																								V																												V							
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																								V																												V	V					
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																								V																												V	V					
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																V	V							V																																		
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																											
S	2004	TrailBlazer EXT	Body	OnStar																																																										
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																																											
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																											
S	2004	TrailBlazer EXT	Body	Navigation Radio																																																											
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																								V																												V	V					

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																								V																											V	V				
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																								
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																								
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																								
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																									
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																								
S	2004	Blazer	Body	Body Control Module																																																								
S	2004	Blazer	Body	Heating and Air Conditioning																																																								
S	2004	Blazer	Body	Instrument Panel Cluster																																																								
S	2004	Blazer	Body	Memory Seat Module																																																								
S	2004	Blazer	Body	Base Radio																																																								
S	2004	Blazer	Body	Uplevel Radio																																																								
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																																								
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																								
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																				V																																				
S	2004	SSR	Chassis	4WAL 3 Sensor																																																									
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																								
S	2004	SSR	Body	Amplifier (Bose)																																																								
S	2004	SSR	Body	Body Control Module																																																								
S	2004	SSR	Body	Driver Seat Module																								V																											V						
S	2004	SSR	Body	Instrument Panel Cluster																V	V							V																																	
S	2004	SSR	Body	Uplevel Radio																																																								
S	2004	SSR	Body	Remote Function Actuation																																																								
S	2004	SSR	Body	Roof and Door Module																																																								
S	2004	SSR	Body	Supplemental Inflatable Restraint																																																								
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																								
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																				V																																				
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																								
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																				V																																				
S	2005	Colorado	Chassis	ABS Without Traction Control																																																								
S	2005	Colorado	Chassis	ABS With Traction Control																																																								
S	2005	Colorado	Body	Body Control Module																																																								
S	2005	Colorado	Body	Instrument Panel Cluster																																																								
S	2005	Colorado	Body	Base Radio																																																								
S	2005	Colorado	Body	Uplevel Radio																																																								
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																																								
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																																								
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																				
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																								
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																								
S	2005	TrailBlazer	Body	Body Control Module																																																								
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																								
S	2005	TrailBlazer	Body	Driver Door Module																																																								
S	2005	TrailBlazer	Body	Driver Seat Module																								V																											V						
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																								V																												V	V				
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																								V																												V	V				
S	2005	TrailBlazer	Body	Instrument Panel Cluster																V	V							V																																	

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2005	TrailBlazer	Body	Lift Gate Module																																																								
S	2005	TrailBlazer	Body	Passenger Door Module																																																								
S	2005	TrailBlazer	Body	Passenger Presence System																																																							V	
S	2005	TrailBlazer	Body	Uplevel Radio																																																							
S	2005	TrailBlazer	Body	Navigation Radio																																																							
S	2005	TrailBlazer	Body	Rear Seat Audio																																																							
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																							
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																							
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																							
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																							
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																				
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																													
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																	
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																							
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																							
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																							
S	2005	TrailBlazer EXT	Body	Body Control Module																																																							
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																							
S	2005	TrailBlazer EXT	Body	Driver Door Module																																																							
S	2005	TrailBlazer EXT	Body	Driver Seat Module																								V																								V							
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																								V																									V	V					
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																								V																									V	V					
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																V	V							V																															
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																							
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																																							
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																						V	
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																							
S	2005	TrailBlazer EXT	Body	Navigation Radio																																																							
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																								V																									V	V					
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																								V																									V	V					
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																							
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																							
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																							
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																							
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																							
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																							
S	2005	Blazer	Body	Body Control Module																																																						
S	2005	Blazer	Body	Heating and Air Conditioning																																																							
S	2005	Blazer	Body	Instrument Panel Cluster																																																							
S	2005	Blazer	Body	Memory Seat Module																																																							
S	2005	Blazer	Body	Base Radio																																																							
S	2005	Blazer	Body	Uplevel Radio																																																							
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																																							
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module						V	V																																																
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																	
S	2005	SSR	Chassis	4WAL 3 Sensor																																																							
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																							
S	2005	SSR	Body	Amplifier (Bose)																																																							
S	2005	SSR	Body	Body Control Module																																																							

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2005	SSR	Body	Driver Seat Module																								V																										V						
S	2005	SSR	Body	Instrument Panel Cluster																V	V							V																																
S	2005	SSR	Body	Uplevel Radio																																																								
S	2005	SSR	Body	Remote Function Actuation																																																								
S	2005	SSR	Body	Roof and Door Module																V	V																																								
S	2005	SSR	Body	Supplemental Inflatable Restraint																																																									
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																				V																																					
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																				V																																					
S	2006	Colorado	Chassis	ABS Without Traction Control																																																									
S	2006	Colorado	Chassis	ABS With Traction Control																																																									
S	2006	Colorado	Body	Body Control Module																																																									
S	2006	Colorado	Body	Instrument Panel Cluster																																																									
S	2006	Colorado	Body	Passenger Presence System																																																								V	
S	2006	Colorado	Body	Base Radio																																																								
S	2006	Colorado	Body	Uplevel Radio																																																								
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																																									
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																																									
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																					
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																															
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																			
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module										V																																															
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																			
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																									
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																									
S	2006	TrailBlazer	Body	Body Control Module																																																									
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																									
S	2006	TrailBlazer	Body	Driver Door Module																																																									
S	2006	TrailBlazer	Body	Driver Seat Module																								V																										V							
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																								V																											V	V					
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																								V																											V	V					
S	2006	TrailBlazer	Body	Instrument Panel Cluster																V	V							V																																		
S	2006	TrailBlazer	Body	Lift Gate Module																																																									
S	2006	TrailBlazer	Body	Passenger Door Module																																																									
S	2006	TrailBlazer	Body	Passenger Presence System																																																								V	
S	2006	TrailBlazer	Body	Uplevel Radio																																																									
S	2006	TrailBlazer	Body	Navigation Radio																																																									
S	2006	TrailBlazer	Body	Rear Seat Audio																																																									
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																									
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																									
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																									
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																					
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																															
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																			
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																									
S	2006	TrailBlazer EXT	Body	Body Control Module																																																									
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																									
S	2006	TrailBlazer EXT	Body	Driver Door Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2006	TrailBlazer EXT	Body	Driver Seat Module																								V																																
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																								V																											V	V				
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																								V																											V	V				
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																V	V							V																																
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																								
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																																								
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																							V	
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																								
S	2006	TrailBlazer EXT	Body	Navigation Radio																																																								
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																								V																											V	V				
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																								V																											V	V				
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																								
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																								
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																								
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																								
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module						V	V																																																	
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																		
S	2006	SSR	Chassis	4WAL 3 Sensor																																																								
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																								
S	2006	SSR	Body	Amplifier (Bose)																																																								
S	2006	SSR	Body	Body Control Module																																																								
S	2006	SSR	Body	Driver Seat Module																								V																																	
S	2006	SSR	Body	Instrument Panel Cluster																V	V							V																																	
S	2006	SSR	Body	Uplevel Radio																																																								
S	2006	SSR	Body	Remote Function Actuation																																																								
S	2006	SSR	Body	Roof and Door Module																V	V																																							
S	2006	SSR	Body	Supplemental Inflatable Restraint																																																								
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																				V																																				
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																				V																																				
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																								
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																								
S	2007	Colorado	Body	Body Control Module																																																								
S	2007	Colorado	Body	Digital Radio Receiver																																																								
S	2007	Colorado	Body	Generator Battery Control Module																																																								
S	2007	Colorado	Body	Instrument Panel Cluster																																																								
S	2007	Colorado	Body	Passenger Presence System																																																							V	
S	2007	Colorado	Body	Base Radio																																																								
S	2007	Colorado	Body	Uplevel Radio																																																								
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																																								
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																																								
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																				
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																								
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																				V																																				
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																			
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																		
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																																			
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																		
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2007	Trailblazer	Body	Body Control Module																																																								
S	2007	Trailblazer	Body	Digital Radio Receiver																																																									
S	2007	Trailblazer	Body	Disc Player and Video Display																																																									
S	2007	Trailblazer	Body	Driver Door Module																																																									
S	2007	Trailblazer	Body	Driver Seat Module																							V																										V							
S	2007	Trailblazer	Body	Generator Battery Control Module																																																									
S	2007	Trailblazer	Body	HVAC Control Module Auto																							V																											V							
S	2007	Trailblazer	Body	HVAC Control Module Manual																							V																											V							
S	2007	Trailblazer	Body	Instrument Panel Cluster																V	V						V																																		
S	2007	Trailblazer	Body	Lift Gate Module																																																									
S	2007	Trailblazer	Body	Passenger Door Module																																																									
S	2007	Trailblazer	Body	Passenger Presence System																																																								V	
S	2007	Trailblazer	Body	Uplevel Radio																																																									
S	2007	Trailblazer	Body	Navigation Radio																																																									
S	2007	Trailblazer	Body	Rear Seat Audio																																																									
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																									
S	2007	Trailblazer	Body	Theft Deterrent Module																																																									
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																									
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																				V	V	V																																			
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																				V	V	V																																			
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																									
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																									
S	2008	Colorado	Body	Body Control Module																																																									
S	2008	Colorado	Body	Digital Radio Receiver																																																									
S	2008	Colorado	Body	Generator Battery Control Module																																																									
S	2008	Colorado	Body	Instrument Panel Cluster																																																									
S	2008	Colorado	Body	Passenger Presence System																																																								V	
S	2008	Colorado	Body	Base Radio																																																									
S	2008	Colorado	Body	Uplevel Radio																																																									
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																																									
S	2008	Colorado	Body	Theft Deterrent Module																																																									
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																																									
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V	V	V																																			
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																				
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																			
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																			
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																									
S	2008	TrailBlazer	Body	Body Control Module																																																									
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																									
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																									
S	2008	TrailBlazer	Body	Driver Door Module																																																									
S	2008	TrailBlazer	Body	Driver Seat Module																							V																										V							
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																									
S	2008	TrailBlazer	Body	HVAC Control Module Auto																							V																											V							
S	2008	TrailBlazer	Body	HVAC Control Module Manual																							V																											V							
S	2008	TrailBlazer	Body	Instrument Panel Cluster																V	V						V																																		
S	2008	TrailBlazer	Body	Lift Gate Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2008	TrailBlazer	Body	Passenger Door Module																																																								
S	2008	TrailBlazer	Body	Passenger Presence System																																																							V	
S	2008	TrailBlazer	Body	Uplevel Radio																																																							
S	2008	TrailBlazer	Body	Navigation Radio																																																							
S	2008	TrailBlazer	Body	Rear Seat Audio																																																							
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																							
S	2008	TrailBlazer	Body	Theft Deterrent Module																																																							
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																							
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																							
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																							
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																							
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																							
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																							
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																							
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																							
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																							
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																							
S	2009	Colorado	Chassis	Electronic Brake Control Module																																																							
S	2009	Colorado	Body	Body Control Module																																																						
S	2009	Colorado	Body	Digital Radio Receiver																																																						
S	2009	Colorado	Body	Generator Battery Control Module																																																						
S	2009	Colorado	Body	Instrument Panel Cluster																																																						
S	2009	Colorado	Body	Passenger Presence System																																																					V	
S	2009	Colorado	Body	Base Radio																																																						
S	2009	Colorado	Body	Uplevel Radio																																																						
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																																						
S	2009	Colorado	Body	Theft Deterrent Module																																																						
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																						
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																						
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																						
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																	
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																						
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																						
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																						
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																						
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																						
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																						
S	2009	TrailBlazer	Body	Body Control Module																																																						
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																						
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																						
S	2009	TrailBlazer	Body	Driver Door Module																																																						
S	2009	TrailBlazer	Body	Driver Seat Module																								V																								V							
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																						
S	2009	TrailBlazer	Body	HVAC Control Module Auto																								V																									V						
S	2009	TrailBlazer	Body	HVAC Control Module Manual																								V																									V						
S	2009	TrailBlazer	Body	Instrument Panel Cluster																V	V							V																															
S	2009	TrailBlazer	Body	Lift Gate Module																																																					
S	2009	TrailBlazer	Body	Passenger Door Module																																																					
S	2009	TrailBlazer	Body	Passenger Presence System																																																					V	
S	2009	TrailBlazer	Body	Uplevel Radio																																																					
S	2009	TrailBlazer	Body	Navigation Radio																																																					

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2009	TrailBlazer	Body	Rear Seat Audio																																																								
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																								
S	2009	TrailBlazer	Body	Theft Deterrent Module																																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
S	2010	ALL	Chassis	Electronic Brake Control Module																																																								
S	2010	ALL	Body	Body Control Module																																																								
S	2010	ALL	Body	Digital Radio Receiver																																																								
S	2010	ALL	Body	Generator Battery Control Module																																																								
S	2010	ALL	Body	Instrument Panel Cluster																																																								
S	2010	ALL	Body	Passenger Presence System																																																							V	
S	2010	ALL	Body	Personal Audio Link Module																										V																														
S	2010	ALL	Body	Base Radio																																																								
S	2010	ALL	Body	Uplevel Radio																																																								
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
S	2010	ALL	Body	Theft Deterrent Module																																																								
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																								
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
S	2011	ALL	Chassis	Electronic Brake Control Module																																																								
S	2011	ALL	Body	Body Control Module																																																								
S	2011	ALL	Body	Digital Radio Receiver																																																								
S	2011	ALL	Body	Generator Battery Control Module																																																								
S	2011	ALL	Body	Instrument Panel Cluster																																																								
S	2011	ALL	Body	Passenger Presence System																																																							V	
S	2011	ALL	Body	Personal Audio Link Module																										V																														
S	2011	ALL	Body	Base Radio																																																								
S	2011	ALL	Body	Uplevel Radio																																																								
S	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
S	2011	ALL	Body	Theft Deterrent Module																																																								
S	2011	ALL	Body	Vehicle Comm. Interface Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																								
S	2012	Colorado (First Gen)	Body	Body Control Module																																																								
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																								
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																								
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																								
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																								V
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																										V																														
S	2012	Colorado (First Gen)	Body	Base Radio																																																								
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																								
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																								
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																								
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																								
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																									V															
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																									V															
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																									V															
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																									V															
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																								
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																								
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																								
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																								
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																								
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2012	Colorado (Second Gen)	Body	Body Control Module																																																								
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																								
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																								
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																									V															
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																									V															
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																									V															
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																									V															
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																								
S	2012	S10	Powertrain	Transfer Case Control Module																																																								
S	2012	S10	Chassis	Electronic Brake Control Module																																																								
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2012	S10	Body	Body Control Module																																																								
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2012	S10	Body	Instrument Cluster																																																								
S	2012	S10	Body	Trailer Interface Control Module																																																								
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																									V												
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																									V												
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																									V												
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																									V												
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																					
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																					
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																					
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																					
S	2013	Colorado	Powertrain	Transfer Case Control Module																																																					
S	2013	Colorado	Chassis	Electronic Brake Control Module																																																					
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																					
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																					
S	2013	Colorado	Body	Body Control Module																																																					
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																					
S	2013	Colorado	Body	Instrument Cluster																																																					
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																					
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																					
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																					
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																					
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																									V												
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																									V												
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																									V												
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																									V												
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																					
S	2013	S10	Powertrain	Transfer Case Control Module																																																					
S	2013	S10	Chassis	Electronic Brake Control Module																																																					
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																					
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																					
S	2013	S10	Body	Body Control Module																																																					
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																					
S	2013	S10	Body	Instrument Cluster																																																					
S	2013	S10	Body	Trailer Interface Control Module																																																					
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																									V												
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																									V												
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																									V												
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																									V												
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																					
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																					
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																					
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																					
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																					
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																					
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																					
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																					
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																					
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																					
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																					
S	2013	Trailblazer	Body	Body Control Module																																																					
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																					
S	2013	Trailblazer	Body	Instrument Cluster																																																					
S	2013	Trailblazer	Body	Trailer Interface Control Module																																																					

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2013	Trailblazer	Body	Parking Assist Control Module																																																								
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																									
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																									
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																									
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2014	Colorado	Body	Body Control Module																																																									
S	2014	Colorado	Body	Body Control Module																																																									
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	Colorado	Body	Instrument Cluster																																																									
S	2014	Colorado	Body	Radio																																																									
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																									
S	2014	Colorado	Body	Parking Assist Control Module																																																									
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2014	S10	Powertrain	Transfer Case Control Module																																																									
S	2014	S10	Chassis	Electronic Brake Control Module																																																									
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
S	2014	S10	Body	Body Control Module																																																									
S	2014	S10	Body	Body Control Module																																																									
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
S	2014	S10	Body	Instrument Cluster																																																									
S	2014	S10	Body	Trailer Interface Control Module																																																									
S	2014	S10	Body	Radio																																																									
S	2014	S10	Body	Parking Assist Control Module																																																									
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																									
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																									
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																									
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																									
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																								
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2014	Trailblazer	Body	Body Control Module																																																								
S	2014	Trailblazer	Body	Body Control Module																																																								
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2014	Trailblazer	Body	Instrument Cluster																																																								
S	2014	Trailblazer	Body	Trailer Interface Control Module																																																								
S	2014	Trailblazer	Body	Parking Assist Control Module																																																								
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2015	Colorado	Powertrain	Chassis Control Module																																																								
S	2015	Colorado	Powertrain	Transfer Case Control Module																																																								
S	2015	Colorado	Chassis	Electronic Brake Control Module																																																								
S	2015	Colorado	Chassis	Power Steering Control Module																																																								
S	2015	Colorado	Body	Body Control Module																																																								
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2015	Colorado	Body	Passenger Presence Module																																																								
S	2015	Colorado	Body	Radio																																																								
S	2015	Colorado	Body	Amplifier																																																								
S	2015	Colorado	Body	Human Machine Interface Control Module																																																								
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																																								
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																								
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																								
S	2015	Colorado	Body	Frontview Camera Module																																																								
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																								
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																								
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2015	Colorado (MMM)	Body	Body Control Module																																																								
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2015	Colorado (MMM)	Body	Instrument Cluster																																																								
S	2015	Colorado (MMM)	Body	Radio																																																								
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																								
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																								
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2015	S10	Powertrain	Transfer Case Control Module																																																								
S	2015	S10	Chassis	Electronic Brake Control Module																																																								
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2015	S10	Body	Body Control Module																																																								
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2015	S10	Body	Instrument Cluster																																																								
S	2015	S10	Body	Trailer Interface Control Module																																																								
S	2015	S10	Body	Radio																																																								
S	2015	S10	Body	Telematics Communication Interface Control Module																																																								
S	2015	S10	Body	Parking Assist Control Module																																																								
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																								
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																								
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																								
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2015	Trailblazer	Body	Body Control Module																																																								
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2015	Trailblazer	Body	Instrument Cluster																																																								
S	2015	Trailblazer	Body	Trailer Interface Control Module																																																								
S	2015	Trailblazer	Body	Radio																																																								
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																								
S	2015	Trailblazer	Body	Parking Assist Control Module																																																								
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																								
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																								
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																								
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																								
S	2016	Colorado (1GC)	Body	Body Control Module																																																								
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																																								
S	2016	Colorado (1GC)	Body	Radio Controls																																																								
S	2016	Colorado (1GC)	Body	HVAC Controls																																																								
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																								
S	2016	Colorado (1GC)	Body	Radio																																																								
S	2016	Colorado (1GC)	Body	Amplifier																																																								
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																								
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																								
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																								
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																								
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																								
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																																								
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																								
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																								
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2016	Colorado (MMM)	Body	Body Control Module																																																								
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2016	Colorado (MMM)	Body	Instrument Cluster																																																								
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																								
S	2016	Colorado (MMM)	Body	Radio																																																								
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																								
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																								
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																								
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																								
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																								
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
S	2016	S10	Powertrain	Transfer Case Control Module																																																								
S	2016	S10	Chassis	Electronic Brake Control Module																																																								
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2016	S10	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2016	S10	Body	Instrument Cluster																																																								
S	2016	S10	Body	Trailer Interface Control Module																																																								
S	2016	S10	Body	Radio																																																								
S	2016	S10	Body	Telematics Communication Interface Control Module																																																								
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																								
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																								
S	2016	S10	Body	Parking Assist Control Module																																																								
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																								
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																								
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																								
S	2016	Trailblazer	Body	Body Control Module																																																								
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
S	2016	Trailblazer	Body	Instrument Cluster																																																								
S	2016	Trailblazer	Body	Trailer Interface Control Module																																																								
S	2016	Trailblazer	Body	Radio																																																								
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																								
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																								
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																								
S	2016	Trailblazer	Body	Parking Assist Control Module																																																								
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
T	2004	S10	Chassis	4WAL 3 Sensor																																																								
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																								
T	2004	S10	Body	Body Control Module																																																								
T	2004	S10	Body	Instrument Panel Cluster																																																								
T	2004	S10	Body	Base Radio																																																								
T	2004	S10	Body	Uplevel Radio																																																								
T	2004	S10	Body	Supplemental Inflatable Restraint																																																								
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																								
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																				V																																				
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																								
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																				V																																				
T	2004	Colorado	Chassis	ABS Without Traction Control																																																								
T	2004	Colorado	Chassis	ABS With Traction Control																																																								
T	2004	Colorado	Body	Body Control Module																																																								
T	2004	Colorado	Body	Instrument Panel Cluster																																																								
T	2004	Colorado	Body	OnStar																																																								
T	2004	Colorado	Body	Base Radio																																																								
T	2004	Colorado	Body	Uplevel Radio																																																								
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																																								
T	2004	Colorado	Body	Instrument Panel Cluster																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																						
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer	Body	Body Control Module																																																										
T	2004	TrailBlazer	Body	Driver Door Module																																																										
T	2004	TrailBlazer	Body	Driver Seat Module																								V																												V						
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																								V																													V	V				
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																								V																													V	V				
T	2004	TrailBlazer	Body	Instrument Panel Cluster																V	V							V																													V	V				
T	2004	TrailBlazer	Body	Lift Gate Module																																																										
T	2004	TrailBlazer	Body	OnStar																																																										
T	2004	TrailBlazer	Body	Passenger Door Module																																																										
T	2004	TrailBlazer	Body	Uplevel Radio																																																										
T	2004	TrailBlazer	Body	Navigation Radio																																																										
T	2004	TrailBlazer	Body	Rear Seat Audio																																																										
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																						
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																				V																																						
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																										
T	2004	TrailBlazer EXT	Body	Body Control Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2004	TrailBlazer EXT	Body	Driver Seat Module																								V																												V						
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																								V																													V	V				
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																								V																													V	V				
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																V	V							V																																		
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2004	TrailBlazer EXT	Body	OnStar																																																										
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2004	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																								V																													V	V				
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																								V																													V	V				
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																										
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																						

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																								
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																								
T	2004	Blazer	Body	Body Control Module																																																								
T	2004	Blazer	Body	Heating and Air Conditioning																																																								
T	2004	Blazer	Body	Instrument Panel Cluster																																																								
T	2004	Blazer	Body	Memory Seat Module																																																								
T	2004	Blazer	Body	Base Radio																																																								
T	2004	Blazer	Body	Uplevel Radio																																																								
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																																								
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																								
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																				V																																				
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																								
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																				V																																				
T	2005	Colorado	Chassis	ABS Without Traction Control																																																								
T	2005	Colorado	Chassis	ABS With Traction Control																																																								
T	2005	Colorado	Body	Body Control Module																																																								
T	2005	Colorado	Body	Instrument Panel Cluster																																																								
T	2005	Colorado	Body	Base Radio																																																								
T	2005	Colorado	Body	Uplevel Radio																																																								
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																																								
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																																								
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																				
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																								
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																								
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																								
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																								
T	2005	TrailBlazer	Body	Body Control Module																																																								
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																								
T	2005	TrailBlazer	Body	Driver Door Module																																																								
T	2005	TrailBlazer	Body	Driver Seat Module																								V																												V				
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																								V																												V	V			
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																								V																												V	V			
T	2005	TrailBlazer	Body	Instrument Panel Cluster																V	V							V																													V			
T	2005	TrailBlazer	Body	Lift Gate Module																																																								
T	2005	TrailBlazer	Body	Passenger Door Module																																																								
T	2005	TrailBlazer	Body	Passenger Presence System																																																								V
T	2005	TrailBlazer	Body	Uplevel Radio																																																								
T	2005	TrailBlazer	Body	Navigation Radio																																																								
T	2005	TrailBlazer	Body	Rear Seat Audio																																																								
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																								
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																								
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																								
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																				
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																														
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																		
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																								
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																								
T	2005	TrailBlazer EXT	Body	Body Control Module																																																								
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																								
T	2005	TrailBlazer EXT	Body	Driver Door Module																																																								
T	2005	TrailBlazer EXT	Body	Driver Seat Module																								V																								V							
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																								V																									V	V					
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																								V																									V	V					
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																V	V							V																															
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																								
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																																								
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																							V	
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																								
T	2005	TrailBlazer EXT	Body	Navigation Radio																																																								
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																								V																									V	V					
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																								V																									V	V					
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																								
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																								
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																								
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																								
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																								
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																								
T	2005	Blazer	Body	Body Control Module																																																								
T	2005	Blazer	Body	Heating and Air Conditioning																																																								
T	2005	Blazer	Body	Instrument Panel Cluster																																																								
T	2005	Blazer	Body	Memory Seat Module																																																								
T	2005	Blazer	Body	Base Radio																																																								
T	2005	Blazer	Body	Uplevel Radio																																																								
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																																								
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																								
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																				V																																				
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																								
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																				V																																				
T	2006	Colorado	Chassis	ABS Without Traction Control																																																								
T	2006	Colorado	Chassis	ABS With Traction Control																																																								
T	2006	Colorado	Body	Body Control Module																																																								
T	2006	Colorado	Body	Instrument Panel Cluster																																																								
T	2006	Colorado	Body	Passenger Presence System																																																						V	
T	2006	Colorado	Body	Base Radio																																																								
T	2006	Colorado	Body	Uplevel Radio																																																								
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																																								
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																																								
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																				
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																													
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																	

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																									
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module										V																																															
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																			
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																										
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																										
T	2006	TrailBlazer	Body	Body Control Module																																																										
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																										
T	2006	TrailBlazer	Body	Driver Door Module																																																										
T	2006	TrailBlazer	Body	Driver Seat Module																								V																									V								
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																								V																										V	V					
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																								V																										V	V					
T	2006	TrailBlazer	Body	Instrument Panel Cluster																V	V							V																																	
T	2006	TrailBlazer	Body	Lift Gate Module																																																										
T	2006	TrailBlazer	Body	Passenger Door Module																																																										
T	2006	TrailBlazer	Body	Passenger Presence System																																																									V	
T	2006	TrailBlazer	Body	Uplevel Radio																																																										
T	2006	TrailBlazer	Body	Navigation Radio																																																										
T	2006	TrailBlazer	Body	Rear Seat Audio																																																										
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																						
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																				
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																										
T	2006	TrailBlazer EXT	Body	Body Control Module																																																										
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
T	2006	TrailBlazer EXT	Body	Driver Door Module																																																										
T	2006	TrailBlazer EXT	Body	Driver Seat Module																								V																									V								
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																								V																										V	V					
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																								V																										V	V					
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																V	V							V																																	
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																										
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																																										
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																									V	
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																										
T	2006	TrailBlazer EXT	Body	Navigation Radio																																																										
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																								V																										V	V					
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																								V																										V	V					
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																										
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																										
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																				V																																						
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																				V																																						

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																									
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																									
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																									
T	2007	Colorado	Body	Body Control Module																																																									
T	2007	Colorado	Body	Digital Radio Receiver																																																									
T	2007	Colorado	Body	Generator Battery Control Module																																																									
T	2007	Colorado	Body	Instrument Panel Cluster																																																									
T	2007	Colorado	Body	Passenger Presence System																																																									
T	2007	Colorado	Body	Base Radio																																																									
T	2007	Colorado	Body	Uplevel Radio																																																									
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																																									
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																																									
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																					
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																									
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																									
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																				V																																					
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																									
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																				
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																		
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																																				
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																		
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																									
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																									
T	2007	Trailblazer	Body	Body Control Module																																																									
T	2007	Trailblazer	Body	Digital Radio Receiver																																																									
T	2007	Trailblazer	Body	Disc Player and Video Display																																																									
T	2007	Trailblazer	Body	Driver Door Module																																																									
T	2007	Trailblazer	Body	Driver Seat Module																								V																									V							
T	2007	Trailblazer	Body	Generator Battery Control Module																																																									
T	2007	Trailblazer	Body	HVAC Control Module Auto																								V																										V						
T	2007	Trailblazer	Body	HVAC Control Module Manual																								V																										V						
T	2007	Trailblazer	Body	Instrument Panel Cluster																V	V							V																																
T	2007	Trailblazer	Body	Lift Gate Module																																																								
T	2007	Trailblazer	Body	Passenger Door Module																																																								
T	2007	Trailblazer	Body	Passenger Presence System																																																								
T	2007	Trailblazer	Body	Uplevel Radio																																																								
T	2007	Trailblazer	Body	Navigation Radio																																																								
T	2007	Trailblazer	Body	Rear Seat Audio																																																								
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																								
T	2007	Trailblazer	Body	Theft Deterrent Module																																																								
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																								
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																				V	V	V																																		
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																				V	V	V																																		
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																								
T	2008	Colorado	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2008	Colorado	Body	Digital Radio Receiver																																																							
T	2008	Colorado	Body	Generator Battery Control Module																																																							
T	2008	Colorado	Body	Instrument Panel Cluster																																																							
T	2008	Colorado	Body	Passenger Presence System																																																							
T	2008	Colorado	Body	Base Radio																																																							
T	2008	Colorado	Body	Uplevel Radio																																																							
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																																							
T	2008	Colorado	Body	Theft Deterrent Module																																																							
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																																							
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																							
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V	V	V																																	
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																							
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																		
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																	
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																							
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																							
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																	
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																							
T	2008	TrailBlazer	Body	Body Control Module																																																							
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																							
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																							
T	2008	TrailBlazer	Body	Driver Door Module																																																							
T	2008	TrailBlazer	Body	Driver Seat Module																								V																									V						
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																							
T	2008	TrailBlazer	Body	HVAC Control Module Auto																								V																										V					
T	2008	TrailBlazer	Body	HVAC Control Module Manual																								V																										V					
T	2008	TrailBlazer	Body	Instrument Panel Cluster																V	V							V																															
T	2008	TrailBlazer	Body	Lift Gate Module																																																							
T	2008	TrailBlazer	Body	Passenger Door Module																																																							
T	2008	TrailBlazer	Body	Passenger Presence System																																																							
T	2008	TrailBlazer	Body	Uplevel Radio																																																							
T	2008	TrailBlazer	Body	Navigation Radio																																																							
T	2008	TrailBlazer	Body	Rear Seat Audio																																																							
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																							
T	2008	TrailBlazer	Body	Theft Deterrent Module																																																							
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																							
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																							
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																							
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																							
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																							
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																							
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																							
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																							
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																							
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																							
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																							
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																							
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																							
T	2009	Colorado	Chassis	Electronic Brake Control Module																																																							
T	2009	Colorado	Body	Body Control Module																																																							
T	2009	Colorado	Body	Digital Radio Receiver																																																							

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2009	Colorado	Body	Generator Battery Control Module																																																								
T	2009	Colorado	Body	Instrument Panel Cluster																																																								
T	2009	Colorado	Body	Passenger Presence System																																																								
T	2009	Colorado	Body	Base Radio																																																								
T	2009	Colorado	Body	Uplevel Radio																																																								
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																																								
T	2009	Colorado	Body	Theft Deterrent Module																																																								
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																								
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																			
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																								
T	2009	TrailBlazer	Body	Body Control Module																																																								
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																								
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																								
T	2009	TrailBlazer	Body	Driver Door Module																																																								
T	2009	TrailBlazer	Body	Driver Seat Module																								V																																
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																								
T	2009	TrailBlazer	Body	HVAC Control Module Auto																								V																															
T	2009	TrailBlazer	Body	HVAC Control Module Manual																								V																															
T	2009	TrailBlazer	Body	Instrument Panel Cluster																V	V							V																															
T	2009	TrailBlazer	Body	Lift Gate Module																																																							
T	2009	TrailBlazer	Body	Passenger Door Module																																																							
T	2009	TrailBlazer	Body	Passenger Presence System																																																							
T	2009	TrailBlazer	Body	Uplevel Radio																																																							
T	2009	TrailBlazer	Body	Navigation Radio																																																							
T	2009	TrailBlazer	Body	Rear Seat Audio																																																							
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																							
T	2009	TrailBlazer	Body	Theft Deterrent Module																																																							
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																							
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																							
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																							
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																							
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																							
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																							
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																							
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																							
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																							
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																							
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																							
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																							
T	2010	ALL	Chassis	Electronic Brake Control Module																																																							
T	2010	ALL	Body	Body Control Module																																																							
T	2010	ALL	Body	Digital Radio Receiver																																																							
T	2010	ALL	Body	Generator Battery Control Module																																																							
T	2010	ALL	Body	Instrument Panel Cluster																																																							
T	2010	ALL	Body	Passenger Presence System																																																							

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2010	ALL	Body	Personal Audio Link Module																										V																														
T	2010	ALL	Body	Base Radio																																																								
T	2010	ALL	Body	Uplevel Radio																																																								
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2010	ALL	Body	Theft Deterrent Module																																																								
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																								
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																								
T	2011	ALL	Chassis	Electronic Brake Control Module																																																								
T	2011	ALL	Body	Body Control Module																																																								
T	2011	ALL	Body	Digital Radio Receiver																																																								
T	2011	ALL	Body	Generator Battery Control Module																																																								
T	2011	ALL	Body	Instrument Panel Cluster																																																								
T	2011	ALL	Body	Passenger Presence System																																																								
T	2011	ALL	Body	Personal Audio Link Module																										V																															
T	2011	ALL	Body	Base Radio																																																								
T	2011	ALL	Body	Uplevel Radio																																																								
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2011	ALL	Body	Theft Deterrent Module																																																								
T	2011	ALL	Body	Vehicle Comm. Interface Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																								
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																								
T	2012	Colorado (First Gen)	Body	Body Control Module																																																								
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																								
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																								
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																								
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																								
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																										V																															
T	2012	Colorado (First Gen)	Body	Base Radio																																																								
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																								
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																									
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																									
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																									
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																									
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																									V															
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																									V															
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																									V															
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																									V															
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																								
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																								
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2012	Colorado (Second Gen)	Body	Body Control Module																																																								
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																								
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																								
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																									V															
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																									V															
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																									V															
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																									V															
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2012	S10	Powertrain	Transfer Case Control Module																																																								
T	2012	S10	Chassis	Electronic Brake Control Module																																																								
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2012	S10	Body	Body Control Module																																																								
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	S10	Body	Instrument Cluster																																																								
T	2012	S10	Body	Trailer Interface Control Module																																																								
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																									V															
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																									V															
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																									V															
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																									V															
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2013	Colorado	Powertrain	Transfer Case Control Module																																																								
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																								
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2013	Colorado	Body	Body Control Module																																																								
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2013	Colorado	Body	Instrument Cluster																																																								
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																										V														
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																										V														
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																										V														
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																										V														
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2013	S10	Powertrain	Transfer Case Control Module																																																								
T	2013	S10	Chassis	Electronic Brake Control Module																																																								
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2013	S10	Body	Body Control Module																																																								
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2013	S10	Body	Instrument Cluster																																																								
T	2013	S10	Body	Trailer Interface Control Module																																																								
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																										V														
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																										V														
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																										V														
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																										V														
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																								
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																								
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																								
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2013	Trailblazer	Body	Body Control Module																																																								
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2013	Trailblazer	Body	Instrument Cluster																																																								
T	2013	Trailblazer	Body	Trailer Interface Control Module																																																								
T	2013	Trailblazer	Body	Parking Assist Control Module																																																								
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																								
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																								
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2014	Colorado	Powertrain	Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																								
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2014	Colorado	Body	Body Control Module																																																								
T	2014	Colorado	Body	Body Control Module																																																								
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2014	Colorado	Body	Instrument Cluster																																																								
T	2014	Colorado	Body	Radio																																																								
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																								
T	2014	Colorado	Body	Parking Assist Control Module																																																								
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																								
T	2014	S10	Powertrain	Transfer Case Control Module																																																								
T	2014	S10	Chassis	Electronic Brake Control Module																																																								
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2014	S10	Body	Body Control Module																																																								
T	2014	S10	Body	Body Control Module																																																								
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2014	S10	Body	Instrument Cluster																																																								
T	2014	S10	Body	Trailer Interface Control Module																																																								
T	2014	S10	Body	Radio																																																								
T	2014	S10	Body	Parking Assist Control Module																																																								
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																								
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																								
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																								
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																								
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																								
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2014	Trailblazer	Body	Body Control Module																																																								
T	2014	Trailblazer	Body	Body Control Module																																																								
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2014	Trailblazer	Body	Instrument Cluster																																																								
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																								
T	2014	Trailblazer	Body	Parking Assist Control Module																																																								
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2015	Colorado	Powertrain	Chassis Control Module																																																									
T	2015	Colorado	Powertrain	Transfer Case Control Module																																																									
T	2015	Colorado	Chassis	Electronic Brake Control Module																																																									
T	2015	Colorado	Chassis	Power Steering Control Module																																																									
T	2015	Colorado	Body	Body Control Module																																																									
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Colorado	Body	Passenger Presence Module																																																									
T	2015	Colorado	Body	Radio																																																									
T	2015	Colorado	Body	Amplifier																																																									
T	2015	Colorado	Body	Human Machine Interface Control Module																																																									
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																																									
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																									
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																									
T	2015	Colorado	Body	Frontview Camera Module																																																									
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																									
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																									
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2015	Colorado (MMM)	Body	Body Control Module																																																									
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Colorado (MMM)	Body	Instrument Cluster																																																									
T	2015	Colorado (MMM)	Body	Radio																																																									
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																									
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																									
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																									
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																									
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																								
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	S10	Powertrain	Transfer Case Control Module																																																									
T	2015	S10	Chassis	Electronic Brake Control Module																																																									
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2015	S10	Body	Body Control Module																																																									
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	S10	Body	Instrument Cluster																																																									
T	2015	S10	Body	Trailer Interface Control Module																																																									
T	2015	S10	Body	Radio																																																									
T	2015	S10	Body	Telematics Communication Interface Control Module																																																									
T	2015	S10	Body	Parking Assist Control Module																																																									
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																									
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																									
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																									
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																									
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																									
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																									
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																									
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																									
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																									
T	2015	Trailblazer	Body	Body Control Module																																																									
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2015	Trailblazer	Body	Instrument Cluster																																																									
T	2015	Trailblazer	Body	Trailer Interface Control Module																																																									
T	2015	Trailblazer	Body	Radio																																																								
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																									
T	2015	Trailblazer	Body	Parking Assist Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																									
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																									
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																									
T	2016	Colorado (1GC)	Body	Body Control Module																																																									
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																																									
T	2016	Colorado (1GC)	Body	Radio Controls																																																									
T	2016	Colorado (1GC)	Body	HVAC Controls																																																									
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																									
T	2016	Colorado (1GC)	Body	Radio																																																									
T	2016	Colorado (1GC)	Body	Amplifier																																																									
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																								
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																								
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																								
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																								
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																								
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																								
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																								
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2016	Colorado (MMM)	Body	Body Control Module																																																								
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																								
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																								
T	2016	Colorado (MMM)	Body	Radio																																																								
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																								
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																								
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																								
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																								
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																								
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
T	2016	S10	Powertrain	Transfer Case Control Module																																																								
T	2016	S10	Chassis	Electronic Brake Control Module																																																								
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2016	S10	Body	Body Control Module																																																								
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2016	S10	Body	Instrument Cluster																																																								
T	2016	S10	Body	Trailer Interface Control Module																																																								
T	2016	S10	Body	Radio																																																								
T	2016	S10	Body	Telematics Communication Interface Control Module																																																								
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																								
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																								
T	2016	S10	Body	Parking Assist Control Module																																																								
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																								
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																								
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																								
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																								
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																								
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2016	Trailblazer	Body	Body Control Module																																																								
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2016	Trailblazer	Body	Instrument Cluster																																																								
T	2016	Trailblazer	Body	Trailer Interface Control Module																																																								
T	2016	Trailblazer	Body	Radio																																																								
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																								
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																								
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																								
T	2016	Trailblazer	Body	Parking Assist Control Module																																																								
V	2009	ALL	Powertrain	Engine Control Module																																																								
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2009	ALL	Powertrain	Rear Drive System																																																								
V	2009	ALL	Powertrain	Transmission Control Module																																																								
V	2009	ALL	Chassis	Electronic Brake Control Module																																																								
V	2009	ALL	Body	Body Control Module																																																								
V	2009	ALL	Body	Digital Radio Receiver																																																								
V	2009	ALL	Body	Driver Door Switch																																																								
V	2009	ALL	Body	Heated Seat Module																																																								
V	2009	ALL	Body	HVAC Control Module Auto																																																								
V	2009	ALL	Body	HVAC Control Module Manual																																																								
V	2009	ALL	Body	Instrument Panel Cluster																																																								
V	2009	ALL	Body	Lift Gate Module																																																								
V	2009	ALL	Body	Park Assist Module																																																								
V	2009	ALL	Body	Passenger Door Switch																																																								
V	2009	ALL	Body	Passenger Presence System																																																								
V	2009	ALL	Body	Radio																																																								
V	2009	ALL	Body	Rear HVAC/RSA																																																								
V	2009	ALL	Body	Rollover Sensor																																																								
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2009	ALL	Body	Theft Deterrent Module																																																								
V	2010	ALL	Powertrain	Engine Control Module																																																								
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2010	ALL	Powertrain	Rear Drive System																																																								
V	2010	ALL	Powertrain	Transmission Control Module																																																								
V	2010	ALL	Chassis	Electronic Brake Control Module																																																								
V	2010	ALL	Body	Body Control Module																																																								
V	2010	ALL	Body	Digital Radio Receiver																																																								
V	2010	ALL	Body	Driver Door Switch																																																								
V	2010	ALL	Body	Heated Seat Module																																																								
V	2010	ALL	Body	HVAC Control Module Auto									V																																														
V	2010	ALL	Body	HVAC Control Module Manual																																																								
V	2010	ALL	Body	Instrument Panel Cluster																																																								
V	2010	ALL	Body	Lift Gate Module																																																								
V	2010	ALL	Body	Park Assist Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
V	2010	ALL	Body	Passenger Door Switch																																																								
V	2010	ALL	Body	Passenger Presence System																																																								
V	2010	ALL	Body	Radio																																																								
V	2010	ALL	Body	Rear HVAC/RSA																																																								
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2010	ALL	Body	Theft Deterrent Module																																																								
V	2011	ALL	Powertrain	Engine Control Module																																																								
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2011	ALL	Powertrain	Rear Drive System																																																								
V	2011	ALL	Powertrain	Transmission Control Module																																																								
V	2011	ALL	Chassis	Electronic Brake Control Module																																																								
V	2011	ALL	Body	Body Control Module																																																								
V	2011	ALL	Body	Digital Radio Receiver																																																								
V	2011	ALL	Body	Driver Door Switch																																																								
V	2011	ALL	Body	Heated Seat Module																																																								
V	2011	ALL	Body	HVAC Control Module Auto									V																																															
V	2011	ALL	Body	HVAC Control Module Manual																																																								
V	2011	ALL	Body	Instrument Panel Cluster																																																								
V	2011	ALL	Body	Lift Gate Module																																																								
V	2011	ALL	Body	Park Assist Module																																																								
V	2011	ALL	Body	Passenger Door Switch																																																								
V	2011	ALL	Body	Passenger Presence System																																																								
V	2011	ALL	Body	Radio																																																								
V	2011	ALL	Body	Rear HVAC/RSA																																																								
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2011	ALL	Body	Theft Deterrent Module																																																								
V	2012	ALL	Powertrain	Engine Control Module																																																								
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2012	ALL	Powertrain	Rear Drive System																																																								
V	2012	ALL	Powertrain	Transmission Control Module																																																								
V	2012	ALL	Chassis	Electronic Brake Control Module																																																								
V	2012	ALL	Body	Body Control Module																																																								
V	2012	ALL	Body	Digital Radio Receiver																																																								
V	2012	ALL	Body	Driver Door Switch																																																								
V	2012	ALL	Body	Heated Seat Module																																																								
V	2012	ALL	Body	HVAC Control Module Auto									V																																															
V	2012	ALL	Body	HVAC Control Module Manual																																																								
V	2012	ALL	Body	Instrument Panel Cluster																																																								
V	2012	ALL	Body	Lift Gate Module																																																								
V	2012	ALL	Body	Park Assist Module																																																								
V	2012	ALL	Body	Passenger Door Switch																																																								
V	2012	ALL	Body	Passenger Presence System																																																								
V	2012	ALL	Body	Radio																																																								
V	2012	ALL	Body	Rear HVAC/RSA																																																								
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2012	ALL	Body	Theft Deterrent Module																																																								
V	2013	ALL	Powertrain	Engine Control Module																																																								
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2013	ALL	Powertrain	Rear Drive System																																																								
V	2013	ALL	Powertrain	Transmission Control Module																																																								
V	2013	ALL	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
V	2013	ALL	Body	Body Control Module																																																										
V	2013	ALL	Body	Digital Radio Receiver																																																										
V	2013	ALL	Body	Driver Door Switch																																																										
V	2013	ALL	Body	Heated Seat Module																																																										
V	2013	ALL	Body	HVAC Control Module Auto									V																																																	
V	2013	ALL	Body	HVAC Control Module Manual																																																										
V	2013	ALL	Body	Instrument Panel Cluster																																																										
V	2013	ALL	Body	Left Side Object Detection Module																																																										
V	2013	ALL	Body	Lift Gate Module																																																										
V	2013	ALL	Body	Park Assist Module																																																										
V	2013	ALL	Body	Passenger Door Switch																																																										
V	2013	ALL	Body	Passenger Presence System																																																										
V	2013	ALL	Body	Radio																																																										
V	2013	ALL	Body	Rear HVAC/RSA																																																										
V	2013	ALL	Body	Right Side Object Detection Module																																																										
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2013	ALL	Body	Theft Deterrent Module																																																										
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2014	Traverse	Powertrain	Chassis Control Module																																																										
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2014	Traverse	Chassis	Electronic Brake Control Module																																															V											
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2014	Traverse	Body	Passenger Presence Module																																																										
V	2014	Traverse	Body	Instrument Cluster																																																										
V	2014	Traverse	Body	Radio																																																										
V	2014	Traverse	Body	Rear Audio Control Module																																																										
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2014	Traverse	Body	Personal Audio Link Control Module																																																V											
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																										
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
V	2014	Traverse	Body	Liftgate Control Module																																																										
V	2014	Traverse	Body	Seat Memory Control Module																																																										
V	2014	Traverse	Body	Front Seat Heating Control Module																																																										
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2014	Traverse	Body	Parking Assist Control Module																																																										
V	2014	Traverse	Body	Frontview Camera Module																																																										
V	2014	Traverse	Body	Theft Deterrent Module																																																										
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2015	Traverse	Chassis	Electronic Brake Control Module																																															V											
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Traverse	Body	Passenger Presence Module																																																										
V	2015	Traverse	Body	Instrument Cluster																																																										
V	2015	Traverse	Body	Radio																																																										
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2015	Traverse	Body	Liftgate Control Module																																																										
V	2015	Traverse	Body	Seat Memory Control Module																																																										
V	2015	Traverse	Body	Front Seat Heating Control Module																																																										
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2015	Traverse	Body	Parking Assist Control Module																																																										
V	2015	Traverse	Body	Frontview Camera Module																																																										
V	2015	Traverse	Body	Theft Deterrent Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Traverse	Chassis	Electronic Brake Control Module																																													V												
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Traverse	Body	Passenger Presence Module																																																										
V	2016	Traverse	Body	Instrument Cluster																																																										
V	2016	Traverse	Body	Radio																																																										
V	2016	Traverse	Body	Rear Audio Control Module																																																										
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2016	Traverse	Body	Personal Audio Link Control Module																																															V											
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																										
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Liftgate Control Module																																																										
V	2016	Traverse	Body	Seat Memory Control Module																																																										
V	2016	Traverse	Body	Front Seat Heating Control Module																																																										
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2016	Traverse	Body	Parking Assist Control Module																																																										
V	2016	Traverse	Body	Frontview Camera Module																																																										
V	2016	Traverse	Body	Theft Deterrent Module																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																									
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																									
A	2011	Orlando	Chassis	Parking Brake Control Module																																																									
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2011	Orlando	Chassis	Power Steering Control Module																																																									
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2011	Orlando	Body	Body Control Module																																																									
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2011	Orlando	Body	Instrument Cluster																																																									
A	2011	Orlando	Body	Trailer Interface Control Module																																																									
A	2011	Orlando	Body	Radio																																																									
A	2011	Orlando	Body	Multimedia Player Interface Module																																																									
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
A	2011	Orlando	Body	Keyless Entry Control Module																																																									
A	2011	Orlando	Body	Parking Assist Control Module																																																									
A	2011	Orlando	Body	Steering Column Lock Control Module																																																									
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																									
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																									
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																									
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																									
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																									
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																									
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																									
A	2012	Orlando	Chassis	Parking Brake Control Module																																																									
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2012	Orlando	Chassis	Power Steering Control Module																																																									
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2012	Orlando	Body	Body Control Module																																																									
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2012	Orlando	Body	Instrument Cluster																																																									
A	2012	Orlando	Body	Trailer Interface Control Module																																																									
A	2012	Orlando	Body	Radio																																																									
A	2012	Orlando	Body	Multimedia Player Interface Module																																																									
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																									
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																									
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																									
A	2012	Orlando	Body	Keyless Entry Control Module																																																									
A	2012	Orlando	Body	Parking Assist Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2012	Orlando	Body	Steering Column Lock Control Module																																																								
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																								
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																								
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																								
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																								
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																								
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																								
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																								
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																								
A	2013	Orlando	Chassis	Parking Brake Control Module																																																								
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2013	Orlando	Chassis	Power Steering Control Module																																																								
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2013	Orlando	Body	Body Control Module																																																								
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2013	Orlando	Body	Instrument Cluster																																																								
A	2013	Orlando	Body	Radio																																																								
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																								
A	2013	Orlando	Body	Multimedia Player Interface Module																																																								
A	2013	Orlando	Body	Mobile Telephone Control Module																																																								
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																								
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																								
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																								
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																								
A	2013	Orlando	Body	Front Seat Heating Control Module																																																								
A	2013	Orlando	Body	Keyless Entry Control Module																																																								
A	2013	Orlando	Body	Parking Assist Control Module																																																								
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																								
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																								
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																								
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																								
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																								
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																								
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																								
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2014	Orlando	Chassis	Power Steering Control Module																																																								
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2014	Orlando	Body	Body Control Module																																																								
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2014	Orlando	Body	Instrument Cluster																																																								
A	2014	Orlando	Body	Radio																																																								
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																								
A	2014	Orlando	Body	Multimedia Player Interface Module																																																								
A	2014	Orlando	Body	Mobile Telephone Control Module																																																								
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																								
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																								
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																								
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																								
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																								
A	2014	Orlando	Body	Front Seat Heating Control Module																																																								
A	2014	Orlando	Body	Rear Seat Heating Control Module																																																								
A	2014	Orlando	Body	Keyless Entry Control Module																																																								
A	2014	Orlando	Body	Parking Assist Control Module																																																								
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																								
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																								
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																								
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																								
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																								
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																								
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
A	2015	Orlando	Chassis	Power Steering Control Module																																																								
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																								
A	2015	Orlando	Body	Body Control Module																																																								
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
A	2015	Orlando	Body	Instrument Cluster																																																								
A	2015	Orlando	Body	Radio																																																								
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																								
A	2015	Orlando	Body	Mobile Telephone Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																									
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
A	2015	Orlando	Body	Front Seat Heating Control Module																																																									
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																									
A	2015	Orlando	Body	Keyless Entry Control Module																																																									
A	2015	Orlando	Body	Parking Assist Control Module																																																									
A	2015	Orlando	Body	Frontview Camera Module																																																									
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																									
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																									
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																									
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																									
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																									
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																									
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2016	Orlando	Chassis	Power Steering Control Module																																																									
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2016	Orlando	Body	Body Control Module																																																								
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2016	Orlando	Body	Instrument Cluster																																																								
A	2016	Orlando	Body	Radio																																																								
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																								
A	2016	Orlando	Body	Multimedia Player Interface Module																																																								
A	2016	Orlando	Body	Mobile Telephone Control Module																																																								
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																								
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																								
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																								
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																								
A	2016	Orlando	Body	Front Seat Heating Control Module																																																								
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																								
A	2016	Orlando	Body	Keyless Entry Control Module																																																								
A	2016	Orlando	Body	Parking Assist Control Module																																																								
A	2016	Orlando	Body	Frontview Camera Module																																																								
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																																																								
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																																																								
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																																																								
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																																																								
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																																																								
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																								
C	2009	N200	Chassis	Electronic Brake Control Module																																																								
C	2009	N200	Body	Supplemental Inflatable Restraint																																																								
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																								
C	2009	N300	Chassis	Electronic Brake Control Module																																																								
C	2009	N300	Body	Supplemental Inflatable Restraint																																																								
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																								
C	2010	N200	Chassis	Electronic Brake Control Module																																																								
C	2010	N200	Body	Supplemental Inflatable Restraint																																																								
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																								
C	2010	N300	Chassis	Electronic Brake Control Module																																																								
C	2010	N300	Body	Supplemental Inflatable Restraint																																																								
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																								
C	2011	N200	Chassis	Electronic Brake Control Module																																																								
C	2011	N200	Body	Supplemental Inflatable Restraint																																																								
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																								
C	2011	N300	Chassis	Electronic Brake Control Module																																																								
C	2011	N300	Body	Supplemental Inflatable Restraint																																																								
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																								
C	2012	N200	Chassis	Electronic Brake Control Module																																																								
C	2012	N200	Body	Supplemental Inflatable Restraint																																																								
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																								
C	2012	N300	Chassis	Electronic Brake Control Module																																																								
C	2012	N300	Body	Supplemental Inflatable Restraint																																																								
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module																																																								
C	2013	N300	Chassis	Electronic Brake Control Module																																																								
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module																																																								
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																																								
C	2014	N300	Chassis	Electronic Brake Control Module																																																								
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module																																																								
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																																								
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																																								
C	2015	Max	Chassis	Electronic Brake Control Module																																																								
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module																																																								
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																																								
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																																								
C	2015	Move	Chassis	Electronic Brake Control Module																																																								
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module																																																								
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																																								
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																																								
C	2015	N300	Chassis	Electronic Brake Control Module																																																								
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module																																																									
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																																									
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																																									
C	2016	Max	Chassis	Electronic Brake Control Module																																																									
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module																																																									
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																																									
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																																									
C	2016	Move	Chassis	Electronic Brake Control Module																																																									
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module																																																									
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																																									
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																																									
C	2016	N300	Chassis	Electronic Brake Control Module																																																									
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																									
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																									
M	2015	City Express	Chassis	Electronic Brake Control Module																																																									
M	2015	City Express	Chassis	Power Steering Control Module																																																									
M	2015	City Express	Body	Body Control Module																																																								
M	2015	City Express	Body	Underhood Fuse Block																																																								
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2015	City Express	Body	Instrument Cluster																																																								
M	2015	City Express	Body	Tire Pressure Indicator Module																																																									
M	2015	City Express	Body	Radio																																																								
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																									
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																									
M	2016	City Express	Chassis	Electronic Brake Control Module																																																									
M	2016	City Express	Chassis	Power Steering Control Module																																																									
M	2016	City Express	Body	Body Control Module																																																								
M	2016	City Express	Body	Underhood Fuse Block																																																								
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
M	2016	City Express	Body	Instrument Cluster																																																								
M	2016	City Express	Body	Tire Pressure Indicator Module																																																									
M	2016	City Express	Body	Radio																																																								
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																									
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																									
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																									
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2011	Orlando	Chassis	Parking Brake Control Module																																																									
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2011	Orlando	Chassis	Power Steering Control Module																																																									
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
P	2011	Orlando	Body	Body Control Module																																																								
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2011	Orlando	Body	Instrument Cluster																																																								
P	2011	Orlando	Body	Trailer Interface Control Module																																																								
P	2011	Orlando	Body	Radio																																																								
P	2011	Orlando	Body	Multimedia Player Interface Module																																																								
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																								
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																								
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																								
P	2011	Orlando	Body	Keyless Entry Control Module																																																								
P	2011	Orlando	Body	Parking Assist Control Module																																																								
P	2011	Orlando	Body	Steering Column Lock Control Module																																																								
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																								
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																								
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																								
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																								
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																								
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																								
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																								
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																																								
P	2012	Orlando	Chassis	Electronic Brake Control Module																																																								
P	2012	Orlando	Chassis	Parking Brake Control Module																																																								
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2012	Orlando	Chassis	Power Steering Control Module																																																								
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2012	Orlando	Body	Body Control Module																																																								
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2012	Orlando	Body	Instrument Cluster																																																								
P	2012	Orlando	Body	Trailer Interface Control Module																																																								
P	2012	Orlando	Body	Radio																																																								
P	2012	Orlando	Body	Multimedia Player Interface Module																																																								
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																								
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																								
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																								
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																								
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																								
P	2012	Orlando	Body	Keyless Entry Control Module																																																								
P	2012	Orlando	Body	Parking Assist Control Module																																																								
P	2012	Orlando	Body	Steering Column Lock Control Module																																																								
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																									
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																									
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																									
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2013	Orlando	Chassis	Parking Brake Control Module																																																									
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2013	Orlando	Chassis	Power Steering Control Module																																																									
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2013	Orlando	Body	Body Control Module																																																									
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2013	Orlando	Body	Instrument Cluster																																																									
P	2013	Orlando	Body	Radio																																																									
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																									
P	2013	Orlando	Body	Multimedia Player Interface Module																																																									
P	2013	Orlando	Body	Mobile Telephone Control Module																																																									
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
P	2013	Orlando	Body	Front Seat Heating Control Module																																																									
P	2013	Orlando	Body	Keyless Entry Control Module																																																									
P	2013	Orlando	Body	Parking Assist Control Module																																																									
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																									
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
P	2014	Orlando	Chassis	Power Steering Control Module																																																									
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2014	Orlando	Body	Body Control Module																																																									
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2014	Orlando	Body	Instrument Cluster																																																									
P	2014	Orlando	Body	Radio																																																									
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																									
P	2014	Orlando	Body	Multimedia Player Interface Module																																																									
P	2014	Orlando	Body	Mobile Telephone Control Module																																																									
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
P	2014	Orlando	Body	Front Seat Heating Control Module																																																									
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																									
P	2014	Orlando	Body	Keyless Entry Control Module																																																									
P	2014	Orlando	Body	Parking Assist Control Module																																																									
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																									
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																									
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																									
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																									
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
P	2015	Orlando	Chassis	Power Steering Control Module																																																									
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
P	2015	Orlando	Body	Body Control Module																																																									
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
P	2015	Orlando	Body	Instrument Cluster																																																									
P	2015	Orlando	Body	Radio																																																									
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																									
P	2015	Orlando	Body	Mobile Telephone Control Module																																																									
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																									
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
P	2015	Orlando	Body	Front Seat Heating Control Module																																																									
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																									
P	2015	Orlando	Body	Keyless Entry Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
P	2015	Orlando	Body	Parking Assist Control Module																																																								
P	2015	Orlando	Body	Frontview Camera Module																																																								
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																								
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																								
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																								
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																								
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																								
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																								
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																								
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																								
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																								
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																								
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																								
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																								
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																								
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																								
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																								
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																								
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																								
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																								
P	2016	Orlando	Chassis	Power Steering Control Module																																																								
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																								
P	2016	Orlando	Body	Body Control Module																																																								
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
P	2016	Orlando	Body	Instrument Cluster																																																								
P	2016	Orlando	Body	Radio																																																								
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																								
P	2016	Orlando	Body	Multimedia Player Interface Module																																																								
P	2016	Orlando	Body	Mobile Telephone Control Module																																																								
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																																								
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																								
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																								
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																								
P	2016	Orlando	Body	Front Seat Heating Control Module																																																								
P	2016	Orlando	Body	Rear Seat Heating Control Module																																																								
P	2016	Orlando	Body	Keyless Entry Control Module																																																								
P	2016	Orlando	Body	Parking Assist Control Module																																																								
P	2016	Orlando	Body	Frontview Camera Module																																																								
U	2004	ALL	Powertrain	Engine Control Module																																																								
U	2004	ALL	Powertrain	Transmission Control Module																																																								
U	2004	ALL	Body	Digital Radio Receiver																																																								
U	2004	ALL	Body	Driver Information Center																																																								
U	2004	ALL	Body	Instrument Panel Cluster																																																								
U	2004	ALL	Body	Radio	V	V	V																																																				
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2004	ALL	Body	Vehicle Theft Deterrent																																																								
U	2005	ALL	Powertrain	Engine Control Module																																																								
U	2005	ALL	Powertrain	Transmission Control Module																																																								
U	2005	ALL	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
U	2005	ALL	Body	Body Control Module																																																								
U	2005	ALL	Body	Disc Player and Video																																																								
U	2005	ALL	Body	Digital Radio Receiver																																																								
U	2005	ALL	Body	HVAC Control Module																																																								
U	2005	ALL	Body	Instrument Panel Cluster																																																								
U	2005	ALL	Body	Left Power Sliding Door Module																																																								
U	2005	ALL	Body	Mobile Digital Media																																																								
U	2005	ALL	Body	Navigation Radio																																																								
U	2005	ALL	Body	Navigation Radio																																																								
U	2005	ALL	Body	Radio																																																								
U	2005	ALL	Body	Right Power Sliding Door Module																																																								
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																								
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																								
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																								
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																								
U	2006	ALL	Chassis	Electronic Brake Control Module																																																								
U	2006	ALL	Body	Body Control Module																																																								
U	2006	ALL	Body	Disc Player and Video																																																								
U	2006	ALL	Body	Digital Radio Receiver																																																								
U	2006	ALL	Body	HVAC Control Module																																																								
U	2006	ALL	Body	Instrument Panel Cluster																																																								
U	2006	ALL	Body	Left Power Sliding Door Module																																																								
U	2006	ALL	Body	Mobile Digital Media																																																								
U	2006	ALL	Body	Navigation Radio																																																								
U	2006	ALL	Body	Navigation Radio																																																								
U	2006	ALL	Body	Radio																																																								
U	2006	ALL	Body	Right Power Sliding Door Module																																																								
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																								
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																								
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
U	2007	ALL	Chassis	Electronic Brake Control Module																																																								
U	2007	ALL	Body	Body Control Module																																																								
U	2007	ALL	Body	Digital Radio Receiver																																																								
U	2007	ALL	Body	Disc Player and Video Display																																																								
U	2007	ALL	Body	HVAC Control Module																																																								
U	2007	ALL	Body	Left Power Sliding Door Module																																																								
U	2007	ALL	Body	Mobile Digital Media																																																								
U	2007	ALL	Body	Radio																																																								
U	2007	ALL	Body	Navigation Radio																																																								
U	2007	ALL	Body	Right Power Sliding Door Module																																																								
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																								
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																								
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
U	2008	ALL	Chassis	Electronic Brake Control Module																																																								
U	2008	ALL	Body	Body Control Module																																																								
U	2008	ALL	Body	Digital Radio Receiver																																																								
U	2008	ALL	Body	Disc Player and Video Display																																																								
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																								
U	2008	ALL	Body	Left Power Sliding Door Module																																																									
U	2008	ALL	Body	Radio																																																									
U	2008	ALL	Body	Navigation Radio																																																									
U	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
U	2008	ALL	Body	Right Power Sliding Door Module																																																										
U	2009	ALL	Powertrain	Engine Control Module																																																										
U	2009	ALL	Powertrain	Transmission Control Module																																																										
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																										
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																										
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																										
U	2009	ALL	Body	Body Control Module																																																										
U	2009	ALL	Body	Digital Radio Receiver																																																										
U	2009	ALL	Body	Disc Player and Video Display																																																										
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																																										
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																										
U	2009	ALL	Body	Instrument Panel Cluster																																																										
U	2009	ALL	Body	Left Power Sliding Door Module																																																										
U	2009	ALL	Body	Radio																																																										
U	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
U	2009	ALL	Body	Right Power Sliding Door Module																																																										
V	2004	ALL	Powertrain	Engine Data Display																																																										
V	2004	ALL	Powertrain	Transmission Data Display																																																										
V	2004	ALL	Body	Digital Radio Receiver																																																										
V	2004	ALL	Body	Driver Information Center																																																										
V	2004	ALL	Body	Instrument Panel Cluster																																																										
V	2004	ALL	Body	Radio	V	V	V																																																						
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2004	ALL	Body	Vehicle Theft Deterrent																																																										
V	2005	Venture	Powertrain	Engine Control Module																																																										
V	2005	Venture	Powertrain	Transmission Control Module																																																										
V	2005	Venture	Body	Digital Radio Receiver																																																										
V	2005	Venture	Body	Driver Information Center																																																										
V	2005	Venture	Body	Instrument Panel Cluster																																																										
V	2005	Venture	Body	Radio	V																																																								
V	2005	Venture	Body	Supplemental Inflatable Restraint																																																										
V	2005	Venture	Body	Vehicle Theft Deterrent																																																										
V	2005	Uplander	Powertrain	Engine Control Module																																																										
V	2005	Uplander	Powertrain	Transmission Control Module																																																										
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																										
V	2005	Uplander	Body	Body Control Module																																																										
V	2005	Uplander	Body	Disc Player and Video																																																										
V	2005	Uplander	Body	Digital Radio Receiver																																																										
V	2005	Uplander	Body	HVAC Control Module																																																										
V	2005	Uplander	Body	Instrument Panel Cluster																																																										
V	2005	Uplander	Body	Left Power Sliding Door Module																																																										
V	2005	Uplander	Body	Mobile Digital Media																																																										
V	2005	Uplander	Body	Navigation Radio																																																										
V	2005	Uplander	Body	Navigation Radio																																																										
V	2005	Uplander	Body	Radio																																																										
V	2005	Uplander	Body	Right Power Sliding Door Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
V	2005	Uplander	Body	Supplemental Inflatable Restraint																																																								
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																								
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																								
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																								
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																								
V	2006	ALL	Chassis	Electronic Brake Control Module																																																								
V	2006	ALL	Body	Body Control Module																																																								
V	2006	ALL	Body	Disc Player and Video																																																								
V	2006	ALL	Body	Digital Radio Receiver																																																								
V	2006	ALL	Body	HVAC Control Module																																																								
V	2006	ALL	Body	Instrument Panel Cluster																																																								
V	2006	ALL	Body	Left Power Sliding Door Module																																																								
V	2006	ALL	Body	Mobile Digital Media																																																								
V	2006	ALL	Body	Navigation Radio																																																								
V	2006	ALL	Body	Navigation Radio																																																								
V	2006	ALL	Body	Radio																																																								
V	2006	ALL	Body	Right Power Sliding Door Module																																																								
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																								
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																								
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
V	2007	ALL	Chassis	Electronic Brake Control Module																																																								
V	2007	ALL	Body	Body Control Module																																																								
V	2007	ALL	Body	Digital Radio Receiver																																																								
V	2007	ALL	Body	Disc Player and Video Display																																																								
V	2007	ALL	Body	HVAC Control Module																																																								
V	2007	ALL	Body	Left Power Sliding Door Module																																																								
V	2007	ALL	Body	Mobile Digital Media																																																								
V	2007	ALL	Body	Radio																																																								
V	2007	ALL	Body	Navigation Radio																																																								
V	2007	ALL	Body	Right Power Sliding Door Module																																																								
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																								
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																								
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																								
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																								
V	2008	ALL	Chassis	Electronic Brake Control Module																																																								
V	2008	ALL	Body	Body Control Module																																																								
V	2008	ALL	Body	Digital Radio Receiver																																																								
V	2008	ALL	Body	Disc Player and Video Display																																																								
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																																								
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																								
V	2008	ALL	Body	Left Power Sliding Door Module																																																								
V	2008	ALL	Body	Radio																																																								
V	2008	ALL	Body	Navigation Radio																																																								
V	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
V	2008	ALL	Body	Right Power Sliding Door Module																																																								
V	2009	ALL	Powertrain	Engine Control Module																																																								
V	2009	ALL	Powertrain	Transmission Control Module																																																								
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																								
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																								
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
V	2009	ALL	Body	Body Control Module																																																								
V	2009	ALL	Body	Digital Radio Receiver																																																								
V	2009	ALL	Body	Disc Player and Video Display																																																								
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																																								
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																								
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																								
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																								
V	2009	ALL	Body	Left Power Sliding Door Module																																																								
V	2009	ALL	Body	Radio																																																								
V	2009	ALL	Body	Remote Control Door Lock Receiver																																																								
V	2009	ALL	Body	Right Power Sliding Door Module																																																								
X	2004	ALL	Powertrain	Engine Control Module																																																								
X	2004	ALL	Powertrain	Transmission Control Module																																																								
X	2004	ALL	Body	Digital Radio Receiver																																																								
X	2004	ALL	Body	Driver Information Center																																																								
X	2004	ALL	Body	Instrument Panel Cluster																																																								
X	2004	ALL	Body	Radio	V	V	V																																																					
X	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
X	2004	ALL	Body	Vehicle Theft Deterrent																																																								
X	2005	ALL	Powertrain	Engine Control Module																																																								
X	2005	ALL	Powertrain	Transmission Control Module																																																								
X	2005	ALL	Chassis	Electronic Brake Control Module																																																								
X	2005	ALL	Body	Body Control Module																																																								
X	2005	ALL	Body	Disc Player and Video																																																								
X	2005	ALL	Body	Digital Radio Receiver																																																								
X	2005	ALL	Body	HVAC Control Module																																																								
X	2005	ALL	Body	Instrument Panel Cluster																																																								
X	2005	ALL	Body	Left Power Sliding Door Module																																																								
X	2005	ALL	Body	Mobile Digital Media																																																								
X	2005	ALL	Body	Navigation Radio																																																								
X	2005	ALL	Body	Navigation Radio																																																								
X	2005	ALL	Body	Radio																																																								
X	2005	ALL	Body	Right Power Sliding Door Module																																																								
X	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																								
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																								
X	2006	ALL	Chassis	Electronic Brake Control Module																																																								
X	2006	ALL	Body	Body Control Module																																																								
X	2006	ALL	Body	Disc Player and Video																																																								
X	2006	ALL	Body	Digital Radio Receiver																																																								
X	2006	ALL	Body	HVAC Control Module																																																								
X	2006	ALL	Body	Instrument Panel Cluster																																																								
X	2006	ALL	Body	Left Power Sliding Door Module																																																								
X	2006	ALL	Body	Mobile Digital Media																																																								
X	2006	ALL	Body	Navigation Radio																																																								
X	2006	ALL	Body	Navigation Radio																																																								
X	2006	ALL	Body	Radio																																																								
X	2006	ALL	Body	Right Power Sliding Door Module																																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																												
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																												
A	2006	ALL	Powertrain	Transmission Control Module																																																												
A	2006	ALL	Chassis	Electronic Brake Control Module																																																												
A	2006	ALL	Chassis	Power Steering Control Module																																																												
A	2006	ALL	Body	Body Control Module																																																												
A	2006	ALL	Body	Digital Radio Receiver																																																												
A	2006	ALL	Body	Instrument Panel Cluster																																																												
A	2006	ALL	Body	Radio																																																												
A	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
A	2006	ALL	Body	Theft Deterrent Module																																																												
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																												
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																												
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																												
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																												
A	2007	ALL	Chassis	Electronic Brake Control Module																																																												
A	2007	ALL	Chassis	Power Steering Control Module																																																												
A	2007	ALL	Body	Body Control Module																																																												
A	2007	ALL	Body	Digital Radio Receiver																																																												
A	2007	ALL	Body	Instrument Panel Cluster																																																												
A	2007	ALL	Body	Radio																																																												
A	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
A	2007	ALL	Body	Theft Deterrent Module																																																												
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																												
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																												
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																												
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																												
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																												
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																												
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES																																																												
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2008	HHR	Chassis	Power Steering Control Module																																																												
A	2008	HHR	Chassis	Power Steering Control Module																																																												
A	2008	HHR	Body	Body Control Module																																																												
A	2008	HHR	Body	Digital Radio Receiver																																																												
A	2008	HHR	Body	Instrument Panel Cluster																																																												
A	2008	HHR	Body	Radio																																																												
A	2008	HHR	Body	Supplemental Inflatable Restraint																																																												
A	2008	HHR	Body	Theft Deterrent Module																																																												
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																												
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																												
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module																																																												
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																																												
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																												
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																												
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																												
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2008	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2008	HHR Panel	Body	Body Control Module																																																												
A	2008	HHR Panel	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2008	HHR Panel	Body	Radio																																																										
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2008	HHR Panel	Body	Theft Deterrent Module																																																										
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																															V	V																										
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																	V																									
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2009	HHR	Chassis	Power Steering Control Module																																																										
A	2009	HHR	Chassis	Power Steering Control Module																																																										
A	2009	HHR	Body	Body Control Module																																																										
A	2009	HHR	Body	Digital Radio Receiver																																																										
A	2009	HHR	Body	Instrument Panel Cluster																																																										
A	2009	HHR	Body	Radio																																																										
A	2009	HHR	Body	Supplemental Inflatable Restraint																																																										
A	2009	HHR	Body	Theft Deterrent Module																																																										
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																										
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																										
A	2009	HHR Panel	Body	Body Control Module																																																										
A	2009	HHR Panel	Body	Digital Radio Receiver																																																										
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																										
A	2009	HHR Panel	Body	Radio																																																										
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																																										
A	2009	HHR Panel	Body	Theft Deterrent Module																																																										
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																										
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																										
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																																										
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																																										
A	2010	HHR	Chassis	Power Steering Control Module																																																										
A	2010	HHR	Chassis	Power Steering Control Module																																																										
A	2010	HHR	Body	Body Control Module																																																										
A	2010	HHR	Body	Digital Radio Receiver																																																										
A	2010	HHR	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
A	2010	HHR	Body	Radio																																																											
A	2010	HHR	Body	Supplemental Inflatable Restraint																																																											
A	2010	HHR	Body	Theft Deterrent Module																																																											
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																											
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																											
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																											
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																											
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																											
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																											
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																											
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2010	HHR Panel	Body	Body Control Module																																																											
A	2010	HHR Panel	Body	Digital Radio Receiver																																																											
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																											
A	2010	HHR Panel	Body	Radio																																																											
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																																											
A	2010	HHR Panel	Body	Theft Deterrent Module																																																											
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																											
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																											
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																											
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																											
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																																											
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2011	HHR	Chassis	Power Steering Control Module																																																											
A	2011	HHR	Body	Body Control Module																																																											
A	2011	HHR	Body	Digital Radio Receiver																																																											
A	2011	HHR	Body	Instrument Panel Cluster																																																											
A	2011	HHR	Body	Radio																																																											
A	2011	HHR	Body	Supplemental Inflatable Restraint																																																											
A	2011	HHR	Body	Theft Deterrent Module																																																											
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																											
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																											
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																											
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																											
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																											
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																											
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																											
A	2011	HHR Panel	Body	Body Control Module																																																											
A	2011	HHR Panel	Body	Digital Radio Receiver																																																											
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																											
A	2011	HHR Panel	Body	Radio																																																											
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																																											
A	2011	HHR Panel	Body	Theft Deterrent Module																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																											
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
A	2013	Trax	Chassis	Electronic Brake Control Module																																																										
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Trax	Chassis	Power Steering Control Module																																																										
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	Trax	Body	Body Control Module																																																									
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	Trax	Body	Passenger Presence Module																																																										
A	2013	Trax	Body	Instrument Cluster																																																										
A	2013	Trax	Body	Radio																																																										
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
A	2013	Trax	Body	Front Seat Heating Control Module																																																										
A	2013	Trax	Body	Parking Assist Control Module																																																										
A	2013	Trax	Body	Frontview Camera Module																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																										
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																													
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																													
A	2014	Trax	Chassis	Electronic Brake Control Module																																																													
A	2014	Trax	Chassis	Power Steering Control Module																																																													
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2014	Trax	Body	Body Control Module																																																													
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2014	Trax	Body	Passenger Presence Module																																																													
A	2014	Trax	Body	Instrument Cluster																																																													
A	2014	Trax	Body	Radio																																																													
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																													
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																													
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																													
A	2014	Trax	Body	Front Seat Heating Control Module																																																													
A	2014	Trax	Body	Parking Assist Control Module																																																													
A	2014	Trax	Body	Frontview Camera Module																																																													
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																													
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																													
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																													
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																													
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																													
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																													
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																													
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																													
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																													
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																													
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																													
A	2015	Trax	Powertrain	Chassis Control Module																																																													
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																													
A	2015	Trax	Chassis	Electronic Brake Control Module																																																													
A	2015	Trax	Chassis	Power Steering Control Module																																																													
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2015	Trax	Body	Body Control Module																																																												
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2015	Trax	Body	Passenger Presence Module																																																												
A	2015	Trax	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
A	2015	Trax	Body	Radio																																																											
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																											
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																											
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																											
A	2015	Trax	Body	Seat Memory Control Module																																																											
A	2015	Trax	Body	Front Seat Heating Control Module																																																											
A	2015	Trax	Body	Right Side Object Detection Control Module																																																											
A	2015	Trax	Body	Left Side Object Detection Control Module																																																											
A	2015	Trax	Body	Parking Assist Control Module																																																											
A	2015	Trax	Body	Frontview Camera Module																																																											
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																											
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																											
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																											
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																											
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																											
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																											
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																											
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																											
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																											
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																											
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																											
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																												
A	2016	Trax	Powertrain	Chassis Control Module																																																											
A	2016	Trax	Chassis	Electronic Brake Control Module																																																											
A	2016	Trax	Chassis	Power Steering Control Module																																																											
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2016	Trax	Body	Body Control Module																																																										
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2016	Trax	Body	Passenger Presence Module																																																											
A	2016	Trax	Body	Instrument Cluster																																																											
A	2016	Trax	Body	Trailer Interface Control Module																																																											
A	2016	Trax	Body	Radio																																																											
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																											
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																											
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																											
A	2016	Trax	Body	Seat Memory Control Module																																																											
A	2016	Trax	Body	Front Seat Heating Control Module																																																											
A	2016	Trax	Body	Right Side Object Detection Control Module																																																											
A	2016	Trax	Body	Left Side Object Detection Control Module																																																											
A	2016	Trax	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
A	2016	Trax	Body	Frontview Camera Module																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																		V	V																					
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																				V																				
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																								
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																					V																			
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																						V																		
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																					V		V																	
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																						V																		
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																						V																		
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																								
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																								
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
C	2004	ALL	Chassis	ESC																																																								
C	2004	ALL	Chassis	Rear Wheel Steering																																																								
C	2004	ALL	Chassis	Tire Pressure Monitor																																																								
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																								
C	2004	ALL	Chassis	VSES																																																								
C	2004	ALL	Body	Amplifier (Bose)																																																								
C	2004	ALL	Body	Body Control Module																																																								
C	2004	ALL	Body	CD Changer																																																								
C	2004	ALL	Body	Chime																																																								
C	2004	ALL	Body	Driver Door Module																																																								
C	2004	ALL	Body	Driver Seat Module																																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																								
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
C	2004	ALL	Body	Instrument Panel Cluster																																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2004	ALL	Body	OnStar																																																												
C	2004	ALL	Body	Passenger Door Module																																																												
C	2004	ALL	Body	Passenger Presence System																																																												
C	2004	ALL	Body	Radio Base																																																												
C	2004	ALL	Body	Radio Uplevel																																																												
C	2004	ALL	Body	Radio Navigation																																																												
C	2004	ALL	Body	Rear Aux. Climate Module	V																																																											
C	2004	ALL	Body	Rear HVAC																																																												
C	2004	ALL	Body	Rear Seat Audio																																																												
C	2004	ALL	Body	Rear Seat Entertainment																																																												
C	2004	ALL	Body	Supplemental Inflatable Restraint		V																																																										
C	2004	ALL	Body	Vehicle Theft Deterrent																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																			V	V																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																						V		V																				
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																							V																				
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																							V																				
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
C	2005	ALL	Chassis	ESC																																																											
C	2005	ALL	Chassis	Rear Wheel Steering																																																												
C	2005	ALL	Chassis	Tire Pressure Monitor																																																												
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2005	ALL	Chassis	VSES																																																									
C	2005	ALL	Body	Amplifier (Bose)																																																									
C	2005	ALL	Body	Body Control Module																																																									
C	2005	ALL	Body	CD Changer																																																									
C	2005	ALL	Body	Chime																																																									
C	2005	ALL	Body	Disc Player and Video Display																																																									
C	2005	ALL	Body	Driver Door Module																																																									
C	2005	ALL	Body	Driver Seat Module																																																									
C	2005	ALL	Body	Generator Battery Control Module																																																									
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																									
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																									
C	2005	ALL	Body	Instrument Panel Cluster																																																									
C	2005	ALL	Body	Passenger Door Module																																																									
C	2005	ALL	Body	Passenger Presence System																																																									
C	2005	ALL	Body	Base Radio																																																									
C	2005	ALL	Body	Uplevel Radio																																																									
C	2005	ALL	Body	Navigation Radio																																																									
C	2005	ALL	Body	Rear Aux. Climate Module	V																																																									
C	2005	ALL	Body	Rear HVAC																																																									
C	2005	ALL	Body	Rear Seat Audio																																																									
C	2005	ALL	Body	Supplemental Inflatable Restraint		V																																																								
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2005	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																			V	V																						
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																								V	V	V	V	V														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																							V					V														

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																								V	V	V													
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																						V	V	V	V	V												
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																					V						V											
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																							V	V	V													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																					
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																					V						V											
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																					
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																					
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																					
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																					
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																					
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																					
C	2006	ALL	Chassis	ESC																																																					
C	2006	ALL	Chassis	Tire Pressure Monitor																																																					
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																					
C	2006	ALL	Chassis	VSES																																																					
C	2006	ALL	Body	Amplifier (Bose)																																																					
C	2006	ALL	Body	Body Control Module																																																					
C	2006	ALL	Body	CD Changer																																																					
C	2006	ALL	Body	Chime																																																					
C	2006	ALL	Body	Disc Player and Video Display																																																					
C	2006	ALL	Body	Driver Door Module																																																					
C	2006	ALL	Body	Driver Seat Module																																																					
C	2006	ALL	Body	Generator Battery Control Module																																																					
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																					
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																					
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																					
C	2006	ALL	Body	Instrument Panel Cluster																																																					
C	2006	ALL	Body	Passenger Door Module																																																					
C	2006	ALL	Body	Passenger Presence System																																																					
C	2006	ALL	Body	Base Radio																																																					
C	2006	ALL	Body	Uplevel Radio																																																					
C	2006	ALL	Body	Navigation Radio																																																					
C	2006	ALL	Body	Rear Aux. Climate Module	V																																																					
C	2006	ALL	Body	Rear HVAC																																																					
C	2006	ALL	Body	Rear Seat Audio																																																					
C	2006	ALL	Body	Supplemental Inflatable Restraint			V																																																		
C	2006	ALL	Body	Vehicle Theft Deterrent																																																					
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																					
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																					
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																												V											
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																					
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																												V											
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																					
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																												V											
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																					
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																												V											
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																	
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES					V																																																	
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																					
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																					

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																											
C	2007	Avalanche	Body	Amplifier (Bose)																																																												
C	2007	Avalanche	Body	Assist Step Controller																																																												
C	2007	Avalanche	Body	Body Control Module																																																												
C	2007	Avalanche	Body	Body Control Module (aux.)																																																												
C	2007	Avalanche	Body	Digital Radio Receiver																																																												
C	2007	Avalanche	Body	Driver Door Switch																																																												
C	2007	Avalanche	Body	HVAC Control Module Auto						V																																																						
C	2007	Avalanche	Body	HVAC Control Module Manual						V																																																						
C	2007	Avalanche	Body	Instrument Panel Cluster																																																												
C	2007	Avalanche	Body	Memory Seat Module							V																																																				
C	2007	Avalanche	Body	Park Assist Module								V																																																			
C	2007	Avalanche	Body	Passenger Door Switch																																																												
C	2007	Avalanche	Body	Passenger Presence System																																																												
C	2007	Avalanche	Body	Radio																																																											
C	2007	Avalanche	Body	Rear Heated Seat Module																																																												
C	2007	Avalanche	Body	Rear HVAC/RSA																																																												
C	2007	Avalanche	Body	Rollover Sensor																																																												
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																												
C	2007	Avalanche	Body	Theft Deterrent Module																																																												
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																							
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES					V																																																							
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Suburban	Chassis	Electronic Suspension Control																																																												
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																												
C	2007	Suburban	Body	Amplifier (Bose)																																																												
C	2007	Suburban	Body	Assist Step Controller																																																												
C	2007	Suburban	Body	Body Control Module																																																												
C	2007	Suburban	Body	Body Control Module (aux.)																																																												
C	2007	Suburban	Body	Digital Radio Receiver																																																												
C	2007	Suburban	Body	Driver Door Switch																																																												
C	2007	Suburban	Body	HVAC Control Module Auto						V																																																						
C	2007	Suburban	Body	HVAC Control Module Manual						V																																																						
C	2007	Suburban	Body	Instrument Panel Cluster																																																												
C	2007	Suburban	Body	Lift Gate Module																																																												
C	2007	Suburban	Body	Memory Seat Module							V																																																				
C	2007	Suburban	Body	Park Assist Module								V																																																			
C	2007	Suburban	Body	Passenger Door Switch																																																												
C	2007	Suburban	Body	Passenger Presence System																																																												
C	2007	Suburban	Body	Radio																																																											
C	2007	Suburban	Body	Rear Heated Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2007	Suburban	Body	Rear HVAC/RSA																																																												
C	2007	Suburban	Body	Rollover Sensor																																																												
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																																												
C	2007	Suburban	Body	Theft Deterrent Module																																																												
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V										
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V								
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																							V					V														
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																						
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2007	Silverado	Chassis	Electronic Suspension Control																																																											
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																											
C	2007	Silverado	Body	Amplifier (Bose)																																																											
C	2007	Silverado	Body	Body Control Module																																																										
C	2007	Silverado	Body	Body Control Module (aux.)																																																											
C	2007	Silverado	Body	Digital Radio Receiver																																																											
C	2007	Silverado	Body	Driver Door Switch																																																											
C	2007	Silverado	Body	HVAC Control Module Auto						V																																										V											
C	2007	Silverado	Body	HVAC Control Module Manual						V																																																					
C	2007	Silverado	Body	Instrument Panel Cluster																																																											
C	2007	Silverado	Body	Memory Seat Module							V																																																				
C	2007	Silverado	Body	Park Assist Module								V																																																		
C	2007	Silverado	Body	Passenger Door Switch																																																											
C	2007	Silverado	Body	Passenger Presence System																																																											
C	2007	Silverado	Body	Radio																																																										
C	2007	Silverado	Body	Rear Heated Seat Module																																																											
C	2007	Silverado	Body	Rear HVAC/RSA																																																											
C	2007	Silverado	Body	Rollover Sensor																																																											
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2007	Silverado	Body	Theft Deterrent Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																													V													
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																													V													
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																													V													
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																							
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES					V																																																							
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																												
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																												
C	2007	Tahoe	Body	Amplifier (Bose)																																																												
C	2007	Tahoe	Body	Assist Step Controller																																																												
C	2007	Tahoe	Body	Body Control Module																																																												
C	2007	Tahoe	Body	Body Control Module (aux.)																																																												
C	2007	Tahoe	Body	Digital Radio Receiver																																																												
C	2007	Tahoe	Body	Driver Door Switch																																																												
C	2007	Tahoe	Body	HVAC Control Module Auto						V																																																						
C	2007	Tahoe	Body	HVAC Control Module Manual						V																																																						
C	2007	Tahoe	Body	Instrument Panel Cluster																																																												
C	2007	Tahoe	Body	Lift Gate Module																																																												
C	2007	Tahoe	Body	Memory Seat Module							V																																																					
C	2007	Tahoe	Body	Park Assist Module								V																																																				
C	2007	Tahoe	Body	Passenger Door Switch																																																												
C	2007	Tahoe	Body	Passenger Presence System																																																												
C	2007	Tahoe	Body	Radio																																																											
C	2007	Tahoe	Body	Rear Heated Seat Module																																																												
C	2007	Tahoe	Body	Rear HVAC/RSA																																																												
C	2007	Tahoe	Body	Rollover Sensor																																																												
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2007	Tahoe	Body	Theft Deterrent Module																																																												
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																													V													
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																													V													
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																													V													
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																													V													
C	2008	Avalanche	Chassis	Electronic Brake Control Module					V																																																							
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																												
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																												
C	2008	Avalanche	Body	Amplifier (Bose)																																																												
C	2008	Avalanche	Body	Assist Step Controller																																																												
C	2008	Avalanche	Body	Body Control Module																																																												
C	2008	Avalanche	Body	Body Control Module (aux.)																																																												
C	2008	Avalanche	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2008	Avalanche	Body	Driver Door Switch																																																												
C	2008	Avalanche	Body	HVAC Control Module Auto						V																																									V											
C	2008	Avalanche	Body	HVAC Control Module Manual						V																																																					
C	2008	Avalanche	Body	Instrument Panel Cluster																																																												
C	2008	Avalanche	Body	Memory Seat Module							V																																																				
C	2008	Avalanche	Body	Park Assist Module								V																																																			
C	2008	Avalanche	Body	Passenger Door Switch																																																											
C	2008	Avalanche	Body	Passenger Presence System																																																											
C	2008	Avalanche	Body	Radio																																																										
C	2008	Avalanche	Body	Rear Heated Seat Module																																																											
C	2008	Avalanche	Body	Rear HVAC/RSA																																																											
C	2008	Avalanche	Body	Rollover Sensor																																																											
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																											
C	2008	Avalanche	Body	Theft Deterrent Module																																																											
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																V											
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																V											
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																V											
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																V											
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES					V																																																						
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW				V																																																							
C	2008	Suburban	Chassis	Electronic Suspension Control																																																											
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																											
C	2008	Suburban	Body	Amplifier (Bose)																																																											
C	2008	Suburban	Body	Assist Step Controller																																																											
C	2008	Suburban	Body	Body Control Module																																																											
C	2008	Suburban	Body	Body Control Module (aux.)																																																											
C	2008	Suburban	Body	Digital Radio Receiver																																																											
C	2008	Suburban	Body	Driver Door Switch																																																											
C	2008	Suburban	Body	HVAC Control Module Auto						V																																																					
C	2008	Suburban	Body	HVAC Control Module Manual						V																																																					
C	2008	Suburban	Body	Instrument Panel Cluster																																																											
C	2008	Suburban	Body	Lift Gate Module																																																											
C	2008	Suburban	Body	Memory Seat Module							V																																																				
C	2008	Suburban	Body	Park Assist Module								V																																																			
C	2008	Suburban	Body	Passenger Door Switch																																																											
C	2008	Suburban	Body	Passenger Presence System																																																											
C	2008	Suburban	Body	Radio																																																											
C	2008	Suburban	Body	Rear Heated Seat Module																																																											
C	2008	Suburban	Body	Rear HVAC/RSA																																																											
C	2008	Suburban	Body	Rollover Sensor																																																											
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2008	Suburban	Body	Theft Deterrent Module																																																												
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																													V														
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																													V														
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																													V														
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																													V														
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																													V														
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																													V														
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																													V														
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V											
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V									
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																							V					V														
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES					V																																																							
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																							
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Silverado	Chassis	Electronic Suspension Control																																																												
C	2008	Silverado	Chassis	Trailer Brake Control Module																																																												
C	2008	Silverado	Body	Amplifier (Bose)																																																												
C	2008	Silverado	Body	Body Control Module																																																											
C	2008	Silverado	Body	Body Control Module (aux.)																																																												
C	2008	Silverado	Body	Digital Radio Receiver																																																												
C	2008	Silverado	Body	Driver Door Switch																																																												
C	2008	Silverado	Body	HVAC Control Module Auto						V																																								V														
C	2008	Silverado	Body	HVAC Control Module Manual						V																																																						
C	2008	Silverado	Body	Instrument Panel Cluster																																																												
C	2008	Silverado	Body	Memory Seat Module							V																																																					
C	2008	Silverado	Body	Park Assist Module								V																																																				
C	2008	Silverado	Body	Passenger Door Switch																																																												
C	2008	Silverado	Body	Passenger Presence System																																																												
C	2008	Silverado	Body	Radio																																																											
C	2008	Silverado	Body	Rear Heated Seat Module																																																												
C	2008	Silverado	Body	Rear HVAC/RSA																																																												
C	2008	Silverado	Body	Rollover Sensor																																																												
C	2008	Silverado	Body	Supplemental Inflatable Restraint																																																												
C	2008	Silverado	Body	Theft Deterrent Module																																																												
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																V	V																												
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																													V														

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																													V													
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																													V													
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
C	2008	Tahoe	Chassis	Electronic Brake Control Module					V																																																						
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																											
C	2008	Tahoe	Body	Amplifier (Bose)																																																											
C	2008	Tahoe	Body	Assist Step Controller																																																											
C	2008	Tahoe	Body	Body Control Module																																																										
C	2008	Tahoe	Body	Body Control Module (aux.)																																																										
C	2008	Tahoe	Body	Digital Radio Receiver																																																										
C	2008	Tahoe	Body	Driver Door Switch																																																										
C	2008	Tahoe	Body	HVAC Control Module Auto						V																																								V												
C	2008	Tahoe	Body	HVAC Control Module Manual						V																																																				
C	2008	Tahoe	Body	Instrument Panel Cluster																																																										
C	2008	Tahoe	Body	Memory Seat Module							V																																																		
C	2008	Tahoe	Body	Park Assist Module								V																																																	
C	2008	Tahoe	Body	Passenger Presence System																																																										
C	2008	Tahoe	Body	Radio																																																									
C	2008	Tahoe	Body	Rear Heated Seat Module																																																										
C	2008	Tahoe	Body	Rear HVAC/RSA																																																										
C	2008	Tahoe	Body	Rollover Sensor																																																										
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2008	Tahoe	Body	Theft Deterrent Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																														V	V		V	V						
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																				V	V			
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																		V																					V	V
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2008	Tahoe Hybrid	Body	Body Control Module																																																										
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2008	Tahoe Hybrid	Body	HVAC Control Module						V																																								V				V							
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2008	Tahoe Hybrid	Body	Memory Seat Module							V																																																		
C	2008	Tahoe Hybrid	Body	Park Assist Module								V																																																	
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2008	Tahoe Hybrid	Body	Radio																																																										
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																																										
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Avalanche	Chassis	Electronic Brake Control Module					V																																																					
C	2009	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2009	Avalanche	Chassis	Trailer Brake Control Module				V																																																						
C	2009	Avalanche	Body	Amplifier (Bose)																																																										
C	2009	Avalanche	Body	Assist Step Controller																																																										
C	2009	Avalanche	Body	Body Control Module																																																										
C	2009	Avalanche	Body	Body Control Module (aux.)																																																										
C	2009	Avalanche	Body	Digital Radio Receiver																																																										
C	2009	Avalanche	Body	Driver Door Switch																																																										
C	2009	Avalanche	Body	HVAC Control Module Auto						V																																										V										
C	2009	Avalanche	Body	HVAC Control Module Manual						V																																																				
C	2009	Avalanche	Body	Instrument Panel Cluster																																																										
C	2009	Avalanche	Body	Memory Seat Module							V																																																			
C	2009	Avalanche	Body	Park Assist Module								V																																																		
C	2009	Avalanche	Body	Passenger Door Switch																																																										
C	2009	Avalanche	Body	Passenger Presence System																																																										
C	2009	Avalanche	Body	Radio																																																										
C	2009	Avalanche	Body	Rear Heated Seat Module																																																										
C	2009	Avalanche	Body	Rear HVAC/RSA																																																										
C	2009	Avalanche	Body	Rollover Sensor																																																										
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2009	Avalanche	Body	Theft Deterrent Module																																																										
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																V										
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																V										
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES					V																																																					

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																							
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
C	2009	Cheyenne	Chassis	Trailer Brake Control Module				V																																																							
C	2009	Cheyenne	Body	Amplifier (Bose)																																																											
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																											
C	2009	Cheyenne	Body	Digital Radio Receiver																																																											
C	2009	Cheyenne	Body	Driver Door Switch																																																											
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																											
C	2009	Cheyenne	Body	Park Assist Module								V																																																		
C	2009	Cheyenne	Body	Passenger Door Switch																																																											
C	2009	Cheyenne	Body	Passenger Presence System																																																											
C	2009	Cheyenne	Body	Rear Heated Seat Module																																																											
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																											
C	2009	Cheyenne	Body	Rollover Sensor																																																											
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
C	2009	Cheyenne	Body	Theft Deterrent Module																																																											
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2009	Suburban	Chassis	EBCM Under 8600 GVW					V																																																						
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW				V																																																							
C	2009	Suburban	Chassis	Electronic Suspension Control																																																											
C	2009	Suburban	Chassis	Trailer Brake Control Module				V																																																							
C	2009	Suburban	Body	Amplifier (Bose)																																																											
C	2009	Suburban	Body	Assist Step Controller																																																											
C	2009	Suburban	Body	Body Control Module																																																										
C	2009	Suburban	Body	Body Control Module (aux.)																																																											
C	2009	Suburban	Body	Digital Radio Receiver																																																											
C	2009	Suburban	Body	Driver Door Switch																																																											
C	2009	Suburban	Body	HVAC Control Module Auto						V																																											V										
C	2009	Suburban	Body	HVAC Control Module Manual						V																																																					
C	2009	Suburban	Body	Instrument Panel Cluster																																																											
C	2009	Suburban	Body	Left Side Object Detection Module																																																											
C	2009	Suburban	Body	Lift Gate Module																																																											
C	2009	Suburban	Body	Memory Seat Module							V																																																				
C	2009	Suburban	Body	Park Assist Module								V																																																			

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2009	Suburban	Body	Passenger Door Switch																																																														
C	2009	Suburban	Body	Passenger Presence System																																																														
C	2009	Suburban	Body	Radio																																																													
C	2009	Suburban	Body	Rear Heated Seat Module																																																													
C	2009	Suburban	Body	Rear HVAC/RSA																																																													
C	2009	Suburban	Body	Right Side Object Detection Module																																																													
C	2009	Suburban	Body	Rollover Sensor																																																													
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																																													
C	2009	Suburban	Body	Theft Deterrent Module																																																													
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																													
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																													
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																													
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																													
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																													
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																													
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																													
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																													
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V												
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V						V											
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																							V					V															
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES					V																																																							
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																							
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES				V																																																								
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2009	Silverado	Chassis	Electronic Suspension Control																																																												
C	2009	Silverado	Chassis	Trailer Brake Control Module				V																																																							
C	2009	Silverado	Body	Amplifier (Bose)																																																												
C	2009	Silverado	Body	Body Control Module																																																											
C	2009	Silverado	Body	Body Control Module (aux.)																																																											
C	2009	Silverado	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2009	Silverado	Body	Driver Door Switch																																																												
C	2009	Silverado	Body	HVAC Control Module Auto						V																																									V											
C	2009	Silverado	Body	HVAC Control Module Manual						V																																																					
C	2009	Silverado	Body	Instrument Panel Cluster																																																											
C	2009	Silverado	Body	Memory Seat Module							V																																																				
C	2009	Silverado	Body	Park Assist Module								V																																																		
C	2009	Silverado	Body	Passenger Door Switch																																																										
C	2009	Silverado	Body	Passenger Presence System																																																										
C	2009	Silverado	Body	Radio																																																										
C	2009	Silverado	Body	Rear Heated Seat Module																																																										
C	2009	Silverado	Body	Rear HVAC/RSA																																																										
C	2009	Silverado	Body	Rollover Sensor																																																										
C	2009	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2009	Silverado	Body	Theft Deterrent Module																																																										
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																															V	V		V	V				
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																				V	V			
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																					V	V
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2009	Silverado Hybrid	Body	Body Control Module																																																										
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2009	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2009	Silverado Hybrid	Body	HVAC Control Module						V																																									V			V							
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2009	Silverado Hybrid	Body	Memory Seat Module							V																																																			
C	2009	Silverado Hybrid	Body	Park Assist Module								V																																																		
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2009	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2009	Silverado Hybrid	Body	Radio																																																										
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2009	Silverado Hybrid	Body	Rollover Sensor																																																										
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																										
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																													V											
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																													V											
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
C	2009	Tahoe	Chassis	Electronic Brake Control Module					V																																																					
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2009	Tahoe	Chassis	Trailer Brake Control Module				V																																																					
C	2009	Tahoe	Body	Amplifier (Bose)																																																									
C	2009	Tahoe	Body	Assist Step Controller																																																									
C	2009	Tahoe	Body	Body Control Module																																																									
C	2009	Tahoe	Body	Body Control Module (aux.)																																																									
C	2009	Tahoe	Body	Digital Radio Receiver																																																									
C	2009	Tahoe	Body	Driver Door Switch																																																									
C	2009	Tahoe	Body	HVAC Control Module Auto						V																																								V											
C	2009	Tahoe	Body	HVAC Control Module Manual						V																																																			
C	2009	Tahoe	Body	Instrument Panel Cluster																																																									
C	2009	Tahoe	Body	Left Side Object Detection Module																																																									
C	2009	Tahoe	Body	Lift Gate Module																																																									
C	2009	Tahoe	Body	Memory Seat Module							V																																																		
C	2009	Tahoe	Body	Park Assist Module								V																																																	
C	2009	Tahoe	Body	Passenger Door Switch																																																									
C	2009	Tahoe	Body	Passenger Presence System																																																									
C	2009	Tahoe	Body	Radio																																																									
C	2009	Tahoe	Body	Rear Heated Seat Module																																																									
C	2009	Tahoe	Body	Rear HVAC/RSA																																																									
C	2009	Tahoe	Body	Right Side Object Detection Module																																																									
C	2009	Tahoe	Body	Rollover Sensor																																																									
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																									
C	2009	Tahoe	Body	Theft Deterrent Module																																																									
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																															V	V		V	V					
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																			V	V			
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																				V	V
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																									
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																									
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																									
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																									
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																									
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																									
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																									
C	2009	Tahoe Hybrid	Body	Body Control Module																																																									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																																												
C	2009	Tahoe Hybrid	Body	HVAC Control Module						V																																										V			V							
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
C	2009	Tahoe Hybrid	Body	Park Assist Module								V																																																			
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																												
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																																												
C	2009	Tahoe Hybrid	Body	Radio																																																												
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																												
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																	
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																																
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Avalanche	Chassis	Electronic Brake Control Module					V																																																							
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																												
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Avalanche	Body	Amplifier (Bose)																																																												
C	2010	Avalanche	Body	Assist Step Controller																																																												
C	2010	Avalanche	Body	Body Control Module																																																												
C	2010	Avalanche	Body	Body Control Module (aux.)																																																												
C	2010	Avalanche	Body	Digital Radio Receiver																																																												
C	2010	Avalanche	Body	Driver Door Switch																																																												
C	2010	Avalanche	Body	HVAC Control Module Auto						V																																										V										
C	2010	Avalanche	Body	HVAC Control Module Manual						V																																																					
C	2010	Avalanche	Body	Instrument Panel Cluster																																																												
C	2010	Avalanche	Body	Memory Seat Module							V																																																				
C	2010	Avalanche	Body	Park Assist Module																																																											
C	2010	Avalanche	Body	Passenger Door Switch																																																											
C	2010	Avalanche	Body	Passenger Presence System																																																											
C	2010	Avalanche	Body	Radio																																																										
C	2010	Avalanche	Body	Rear Heated Seat Module																																																											
C	2010	Avalanche	Body	Rear HVAC/RSA																																																											
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																											
C	2010	Avalanche	Body	Theft Deterrent Module																																																											
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																																
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES					V																																																					
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES					V																																																					
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																						
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Cheyenne	Body	Amplifier (Bose)																																																										
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2010	Cheyenne	Body	Digital Radio Receiver																																																										
C	2010	Cheyenne	Body	Driver Door Switch																																																										
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2010	Cheyenne	Body	Park Assist Module																																																										
C	2010	Cheyenne	Body	Passenger Door Switch																																																										
C	2010	Cheyenne	Body	Passenger Presence System																																																										
C	2010	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2010	Cheyenne	Body	Theft Deterrent Module																																																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																															
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																														
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Suburban	Chassis	EBCM Under 8600 GVW					V																																																						
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW				V																																																							
C	2010	Suburban	Chassis	Electronic Suspension Control																																																										
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Suburban	Body	Amplifier (Bose)																																																										
C	2010	Suburban	Body	Assist Step Controller																																																										
C	2010	Suburban	Body	Body Control Module																																																										
C	2010	Suburban	Body	Body Control Module (aux.)																																																										
C	2010	Suburban	Body	Digital Radio Receiver																																																										
C	2010	Suburban	Body	Driver Door Switch																																																										
C	2010	Suburban	Body	HVAC Control Module Auto						V																																										V											
C	2010	Suburban	Body	HVAC Control Module Manual						V																																																					
C	2010	Suburban	Body	Instrument Panel Cluster																																																										
C	2010	Suburban	Body	Left Side Object Detection Module																																																										
C	2010	Suburban	Body	Lift Gate Module																																																										
C	2010	Suburban	Body	Memory Seat Module							V																																																			
C	2010	Suburban	Body	Park Assist Module																																																										
C	2010	Suburban	Body	Passenger Door Switch																																																										
C	2010	Suburban	Body	Passenger Presence System																																																										
C	2010	Suburban	Body	Radio																																																										
C	2010	Suburban	Body	Rear Heated Seat Module																																																										
C	2010	Suburban	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2010	Suburban	Body	Right Side Object Detection Module																																																												
C	2010	Suburban	Body	Supplemental Inflatable Restraint																																																												
C	2010	Suburban	Body	Theft Deterrent Module																																																												
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module											V	V																																															
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																	
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																																	
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																	
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																												
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																																
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V											
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V										
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																							V					V															
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES					V																																																						
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES				V																																																							
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2010	Silverado	Chassis	Electronic Suspension Control																																																											
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control				V																																																							
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2010	Silverado	Body	Amplifier (Bose)																																																											
C	2010	Silverado	Body	Body Control Module																																																										
C	2010	Silverado	Body	Body Control Module (aux.)																																																											
C	2010	Silverado	Body	Digital Radio Receiver																																																											
C	2010	Silverado	Body	Driver Door Switch																																																										
C	2010	Silverado	Body	HVAC Control Module Auto						V																																											V										
C	2010	Silverado	Body	HVAC Control Module Manual						V																																																				
C	2010	Silverado	Body	Instrument Panel Cluster																																																											
C	2010	Silverado	Body	Memory Seat Module							V																																																			
C	2010	Silverado	Body	Park Assist Module																																																										
C	2010	Silverado	Body	Passenger Door Switch																																																										
C	2010	Silverado	Body	Passenger Presence System																																																										
C	2010	Silverado	Body	Radio																																																										
C	2010	Silverado	Body	Rear Heated Seat Module																																																										
C	2010	Silverado	Body	Rear HVAC/RSA																																																										
C	2010	Silverado	Body	Supplemental Inflatable Restraint																																																										
C	2010	Silverado	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																													V	V		V	V				
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																				
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																	V	V		
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																				
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																		V																		V	V
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																				
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																				
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																				
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																				
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																				
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																				
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																				
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																				
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																				
C	2010	Silverado Hybrid	Body	Body Control Module																																																				
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																				
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																				
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																				
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																				
C	2010	Silverado Hybrid	Body	HVAC Control Module						V																																											V							
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																				
C	2010	Silverado Hybrid	Body	Park Assist Module																																																				
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																				
C	2010	Silverado Hybrid	Body	Passenger Presence System																																																				
C	2010	Silverado Hybrid	Body	Radio																																																				
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																				
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																				
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																				
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																				
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																				
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																										
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																				
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																				
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																				
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																				
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																				
C	2010	Tahoe	Chassis	Electronic Brake Control Module					V																																															
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																				
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																				
C	2010	Tahoe	Body	Amplifier (Bose)																																																				
C	2010	Tahoe	Body	Assist Step Controller																																																				
C	2010	Tahoe	Body	Body Control Module																																																				
C	2010	Tahoe	Body	Body Control Module (aux.)																																																				
C	2010	Tahoe	Body	Digital Radio Receiver																																																				
C	2010	Tahoe	Body	Driver Door Switch																																																				
C	2010	Tahoe	Body	HVAC Control Module Auto						V																																							V									
C	2010	Tahoe	Body	HVAC Control Module Manual						V																																															
C	2010	Tahoe	Body	Instrument Panel Cluster																																																				
C	2010	Tahoe	Body	Left Side Object Detection Module																																																				
C	2010	Tahoe	Body	Lift Gate Module																																																				
C	2010	Tahoe	Body	Memory Seat Module							V																																													

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2010	Tahoe	Body	Park Assist Module																																																												
C	2010	Tahoe	Body	Passenger Door Switch																																																												
C	2010	Tahoe	Body	Passenger Presence System																																																												
C	2010	Tahoe	Body	Radio																																																												
C	2010	Tahoe	Body	Rear Heated Seat Module																																																												
C	2010	Tahoe	Body	Rear HVAC/RSA																																																												
C	2010	Tahoe	Body	Right Side Object Detection Module																																																												
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2010	Tahoe	Body	Theft Deterrent Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2010	Tahoe Hybrid	Body	Body Control Module																																																												
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																																												
C	2010	Tahoe Hybrid	Body	HVAC Control Module					V																																													V									
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																																												
C	2010	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																												
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																																												
C	2010	Tahoe Hybrid	Body	Radio																																																												
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																																	
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																	
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2011	Avalanche	Chassis	Electronic Brake Control Module					V																																																							
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																												
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2011	Avalanche	Body	Amplifier (Bose)																																																												
C	2011	Avalanche	Body	Assist Step Controller																																																												
C	2011	Avalanche	Body	Body Control Module																																																												
C	2011	Avalanche	Body	Body Control Module (aux.)																																																												
C	2011	Avalanche	Body	Digital Radio Receiver																																																												
C	2011	Avalanche	Body	Driver Door Switch																																																												
C	2011	Avalanche	Body	HVAC Control Module Auto						V																																												V										
C	2011	Avalanche	Body	HVAC Control Module Manual						V																																																						
C	2011	Avalanche	Body	Instrument Panel Cluster																																																												
C	2011	Avalanche	Body	Memory Seat Module							V																																																				
C	2011	Avalanche	Body	Park Assist Module																																																												
C	2011	Avalanche	Body	Passenger Door Switch																																																												
C	2011	Avalanche	Body	Passenger Presence System																																																												
C	2011	Avalanche	Body	Radio																																																												
C	2011	Avalanche	Body	Rear Heated Seat Module																																																												
C	2011	Avalanche	Body	Rear HVAC/RSA																																																												
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																												
C	2011	Avalanche	Body	Theft Deterrent Module																																																												
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																												
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																												
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																												
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																												
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																												
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																												
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
C	2011	Captiva	Chassis	Electronic Brake Control Module																																																												
C	2011	Captiva	Chassis	Parking Brake Control Module																																																												
C	2011	Captiva	Body	Body Control Module																																																												
C	2011	Captiva	Body	Auxiliary Body Control Module																																																												
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2011	Captiva	Body	Instrument Cluster																																																												
C	2011	Captiva	Body	Headlamp Control Module																																																												
C	2011	Captiva	Body	HVAC Control Module																																																												
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																												
C	2011	Captiva	Body	Parking Assist Control Module																									V																																		
C	2011	Captiva	Body	Theft Deterrent Module																																																												
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																																
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES					V																																																						
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES					V																																																						
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																							
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																											
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
C	2011	Cheyenne	Body	Amplifier (Bose)																																																											
C	2011	Cheyenne	Body	Body Control Module																																																											
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																											
C	2011	Cheyenne	Body	Digital Radio Receiver																																																											
C	2011	Cheyenne	Body	Driver Door Switch																																																											
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																											
C	2011	Cheyenne	Body	Park Assist Module																																																											
C	2011	Cheyenne	Body	Passenger Door Switch																																																											
C	2011	Cheyenne	Body	Passenger Presence System																																																											
C	2011	Cheyenne	Body	Rear Heated Seat Module																																																											
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																											
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
C	2011	Cheyenne	Body	Theft Deterrent Module																																																											
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																																
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW				V																																																							
C	2011	Suburban	Chassis	EBCM Under 8600 GVW					V																																																						
C	2011	Suburban	Chassis	Electronic Suspension Control																																																											
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
C	2011	Suburban	Body	Amplifier (Bose)																																																											
C	2011	Suburban	Body	Assist Step Controller																																																											
C	2011	Suburban	Body	Body Control Module																																																											
C	2011	Suburban	Body	Body Control Module (aux.)																																																											
C	2011	Suburban	Body	Digital Radio Receiver																																																											
C	2011	Suburban	Body	Driver Door Switch																																																											
C	2011	Suburban	Body	HVAC Control Module Auto						V																																											V											
C	2011	Suburban	Body	HVAC Control Module Manual						V																																																					
C	2011	Suburban	Body	Instrument Panel Cluster																																																											
C	2011	Suburban	Body	Left Side Object Detection Module																																																											
C	2011	Suburban	Body	Lift Gate Module																																																											
C	2011	Suburban	Body	Memory Seat Module							V																																																				
C	2011	Suburban	Body	Park Assist Module																																																											
C	2011	Suburban	Body	Passenger Door Switch																																																											
C	2011	Suburban	Body	Passenger Presence System																																																											
C	2011	Suburban	Body	Radio																																																											
C	2011	Suburban	Body	Rear Heated Seat Module																																																											
C	2011	Suburban	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2011	Suburban	Body	Right Side Object Detection Module																																																												
C	2011	Suburban	Body	Supplemental Inflatable Restraint																																																												
C	2011	Suburban	Body	Theft Deterrent Module																																																												
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module											V	V																																															
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																	
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																																	
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																												
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual									V		V																																																	
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module									V	V	V																																																	
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																									V	V	V	V				V	V											
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																									V	V	V																
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																							V						V														
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																									V	V	V	V				V	V											
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																									V	V	V																
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES					V																																																							
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																							
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES				V																																																								
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2011	Silverado	Chassis	Electronic Suspension Control																																																												
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
C	2011	Silverado	Body	Amplifier (Bose)																																																												
C	2011	Silverado	Body	Body Control Module																																																											
C	2011	Silverado	Body	Body Control Module (aux.)																																																											
C	2011	Silverado	Body	Digital Radio Receiver																																																											
C	2011	Silverado	Body	Driver Door Switch																																																											
C	2011	Silverado	Body	HVAC Control Module Auto						V																																											V										
C	2011	Silverado	Body	HVAC Control Module Manual						V																																																					
C	2011	Silverado	Body	Instrument Panel Cluster																																																											
C	2011	Silverado	Body	Memory Seat Module							V																																																				
C	2011	Silverado	Body	Park Assist Module																																																											
C	2011	Silverado	Body	Passenger Door Switch																																																											
C	2011	Silverado	Body	Passenger Presence System																																																											
C	2011	Silverado	Body	Radio																																																											
C	2011	Silverado	Body	Rear Heated Seat Module																																																											
C	2011	Silverado	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2011	Silverado	Body	Theft Deterrent Module																																																												
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																															V	V		V	V				
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																				V	V			
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																		V																						V	V
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Silverado Hybrid	Body	Body Control Module																																																										
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																										
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																										
C	2011	Silverado Hybrid	Body	HVAC Control Module						V																																													V								
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Silverado Hybrid	Body	Park Assist Module																																																										
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																										
C	2011	Silverado Hybrid	Body	Passenger Presence System																																																										
C	2011	Silverado Hybrid	Body	Radio																																																										
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2011	Tahoe	Chassis	Electronic Brake Control Module					V																																																					
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe	Body	Amplifier (Bose)																																																										
C	2011	Tahoe	Body	Assist Step Controller																																																										
C	2011	Tahoe	Body	Body Control Module																																																										
C	2011	Tahoe	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe	Body	Digital Radio Receiver																																																										
C	2011	Tahoe	Body	Driver Door Switch																																																										
C	2011	Tahoe	Body	HVAC Control Module Auto						V																																										V										
C	2011	Tahoe	Body	HVAC Control Module Manual						V																																																				
C	2011	Tahoe	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe	Body	Left Side Object Detection Module																																																										
C	2011	Tahoe	Body	Lift Gate Module																																																										
C	2011	Tahoe	Body	Memory Seat Module							V																																																			
C	2011	Tahoe	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2011	Tahoe	Body	Passenger Door Switch																																																										
C	2011	Tahoe	Body	Passenger Presence System																																																										
C	2011	Tahoe	Body	Radio																																																										
C	2011	Tahoe	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe	Body	Right Side Object Detection Module																																																										
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2011	Tahoe	Body	Theft Deterrent Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2011	Tahoe Hybrid	Body	Body Control Module																																																										
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2011	Tahoe Hybrid	Body	HVAC Control Module						V																																													V							
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2011	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2011	Tahoe Hybrid	Body	Radio																																																										
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2012	Avalanche	Chassis	Electronic Brake Control Module					V																																																					
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2012	Avalanche	Body	Amplifier (Bose)																																																											
C	2012	Avalanche	Body	Assist Step Controller																																																											
C	2012	Avalanche	Body	Body Control Module																																																											
C	2012	Avalanche	Body	Body Control Module (aux.)																																																											
C	2012	Avalanche	Body	Digital Radio Receiver																																																											
C	2012	Avalanche	Body	Driver Door Switch																																																											
C	2012	Avalanche	Body	HVAC Control Module Auto						V																																												V									
C	2012	Avalanche	Body	HVAC Control Module Manual						V																																																					
C	2012	Avalanche	Body	Instrument Panel Cluster																																																											
C	2012	Avalanche	Body	Memory Seat Module							V																																																			
C	2012	Avalanche	Body	Navigation Radio																																																											
C	2012	Avalanche	Body	Park Assist Module																																																											
C	2012	Avalanche	Body	Passenger Door Switch																																																											
C	2012	Avalanche	Body	Passenger Presence System																																																											
C	2012	Avalanche	Body	Radio																																																											
C	2012	Avalanche	Body	Rear Heated Seat Module																																																											
C	2012	Avalanche	Body	Rear HVAC/RSA																																																											
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																											
C	2012	Avalanche	Body	Theft Deterrent Module																																																											
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																											
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																											
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																											
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																											
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																											
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																											
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																											
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																											
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																											
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																											
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																											
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																											
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																											
C	2012	Captiva	Chassis	Parking Brake Control Module																																																											
C	2012	Captiva	Body	Body Control Module																																																											
C	2012	Captiva	Body	Auxiliary Body Control Module																																																											
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2012	Captiva	Body	Instrument Cluster																																																											
C	2012	Captiva	Body	Headlamp Control Module																																																											
C	2012	Captiva	Body	HVAC Control Module																																																											
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																											
C	2012	Captiva	Body	Parking Assist Control Module																									V																																		

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2012	Captiva	Body	Theft Deterrent Module																																																											
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V														
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES					V																																																						
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																							
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																											
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
C	2012	Cheyenne	Body	Amplifier (Bose)																																																											
C	2012	Cheyenne	Body	Body Control Module																																																											
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																											
C	2012	Cheyenne	Body	Digital Radio Receiver																																																											
C	2012	Cheyenne	Body	Driver Door Switch																																																											
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																											
C	2012	Cheyenne	Body	Park Assist Module																																																											
C	2012	Cheyenne	Body	Passenger Door Switch																																																											
C	2012	Cheyenne	Body	Passenger Presence System																																																											
C	2012	Cheyenne	Body	Rear Heated Seat Module																																																											
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																											
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
C	2012	Cheyenne	Body	Theft Deterrent Module																																																											
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																																
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed									V	V	V																																																
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2012	Suburban	Chassis	EBCM Under 8600 GVW					V																																																						
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW				V																																																							
C	2012	Suburban	Chassis	Electronic Suspension Control																																																											
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
C	2012	Suburban	Body	Amplifier (Bose)																																																											
C	2012	Suburban	Body	Assist Step Controller																																																											
C	2012	Suburban	Body	Body Control Module																																																											
C	2012	Suburban	Body	Body Control Module (aux.)																																																											
C	2012	Suburban	Body	Digital Radio Receiver																																																											
C	2012	Suburban	Body	Driver Door Switch																																																											
C	2012	Suburban	Body	HVAC Control Module Auto						V																																																					
C	2012	Suburban	Body	HVAC Control Module Manual						V																																																					
C	2012	Suburban	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2012	Suburban	Body	Left Side Object Detection Module																																																												
C	2012	Suburban	Body	Lift Gate Module																																																												
C	2012	Suburban	Body	Memory Seat Module							V																																																				
C	2012	Suburban	Body	Navigation Radio																																																											
C	2012	Suburban	Body	Park Assist Module																																																											
C	2012	Suburban	Body	Passenger Door Switch																																																											
C	2012	Suburban	Body	Passenger Presence System																																																											
C	2012	Suburban	Body	Radio																																																											
C	2012	Suburban	Body	Rear Heated Seat Module																																																											
C	2012	Suburban	Body	Rear HVAC/RSA																																																											
C	2012	Suburban	Body	Right Side Object Detection Module																																																											
C	2012	Suburban	Body	Supplemental Inflatable Restraint																																																											
C	2012	Suburban	Body	Theft Deterrent Module																																																											
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																											
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																											
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																																
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																																
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																											
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual									V		V																																																
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module									V	V	V																																																
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																									V	V	V	V				V	V										
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																									V	V	V																
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																							V						V													
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																									V	V	V	V				V	V										
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																									V	V	V																
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																											
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES					V																																																						
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES				V																																																							
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2012	Silverado	Chassis	Electronic Suspension Control																																																											
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2012	Silverado	Body	Amplifier (Bose)																																																											
C	2012	Silverado	Body	Body Control Module																																																											
C	2012	Silverado	Body	Body Control Module (aux.)																																																											
C	2012	Silverado	Body	Digital Radio Receiver																																																											
C	2012	Silverado	Body	Driver Door Switch																																																											
C	2012	Silverado	Body	HVAC Control Module Auto						V																																																					

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2012	Silverado	Body	HVAC Control Module Manual						V																																																					
C	2012	Silverado	Body	Instrument Panel Cluster																																																												
C	2012	Silverado	Body	Memory Seat Module							V																																																				
C	2012	Silverado	Body	Navigation Radio																																																											
C	2012	Silverado	Body	Park Assist Module																																																											
C	2012	Silverado	Body	Passenger Door Switch																																																											
C	2012	Silverado	Body	Passenger Presence System																																																											
C	2012	Silverado	Body	Radio																																																											
C	2012	Silverado	Body	Rear Heated Seat Module																																																											
C	2012	Silverado	Body	Rear HVAC/RSA																																																											
C	2012	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2012	Silverado	Body	Theft Deterrent Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																	V	V		V	V				
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																					V	V		
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																					V	V
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																											
C	2012	Silverado Hybrid	Body	Body Control Module																																																											
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																											
C	2012	Silverado Hybrid	Body	Driver Door Switch																																																											
C	2012	Silverado Hybrid	Body	Heated Seat Module																																																											
C	2012	Silverado Hybrid	Body	HVAC Control Module						V																																														V							
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
C	2012	Silverado Hybrid	Body	Navigation Radio																																																											
C	2012	Silverado Hybrid	Body	Park Assist Module																																																											
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2012	Silverado Hybrid	Body	Passenger Presence System																																																											
C	2012	Silverado Hybrid	Body	Radio																																																											
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																											
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2012	Tahoe	Chassis	Electronic Brake Control Module					V																																																						
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2012	Tahoe	Body	Amplifier (Bose)																																																											
C	2012	Tahoe	Body	Assist Step Controller																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2012	Tahoe	Body	Body Control Module																																																												
C	2012	Tahoe	Body	Body Control Module (aux.)																																																												
C	2012	Tahoe	Body	Digital Radio Receiver																																																												
C	2012	Tahoe	Body	Driver Door Switch																																																												
C	2012	Tahoe	Body	HVAC Control Module Auto						V																																									V												
C	2012	Tahoe	Body	HVAC Control Module Manual						V																																																						
C	2012	Tahoe	Body	Instrument Panel Cluster																																																												
C	2012	Tahoe	Body	Left Side Object Detection Module																																																												
C	2012	Tahoe	Body	Lift Gate Module																																																												
C	2012	Tahoe	Body	Memory Seat Module							V																																																					
C	2012	Tahoe	Body	Navigation Radio																																																												
C	2012	Tahoe	Body	Park Assist Module																																																												
C	2012	Tahoe	Body	Passenger Door Switch																																																												
C	2012	Tahoe	Body	Passenger Presence System																																																												
C	2012	Tahoe	Body	Radio																																																												
C	2012	Tahoe	Body	Rear Heated Seat Module																																																												
C	2012	Tahoe	Body	Rear HVAC/RSA																																																												
C	2012	Tahoe	Body	Right Side Object Detection Module																																																												
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2012	Tahoe	Body	Theft Deterrent Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																V	V		V	V						
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																					V	V			
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																						V	V
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
C	2012	Tahoe Hybrid	Body	Body Control Module																																																												
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																																												
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																																												
C	2012	Tahoe Hybrid	Body	HVAC Control Module						V																																												V										
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
C	2012	Tahoe Hybrid	Body	Lift Gate Module																																																												
C	2012	Tahoe Hybrid	Body	Navigation Radio																																																												
C	2012	Tahoe Hybrid	Body	Park Assist Module																																																												
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																												
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																																												
C	2012	Tahoe Hybrid	Body	Radio																																																												
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Avalanche	Chassis	Electronic Brake Control Module					V																																																					
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																										
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Avalanche	Body	Amplifier (Bose)																																																										
C	2013	Avalanche	Body	Assist Step Controller																																																										
C	2013	Avalanche	Body	Body Control Module																																																										
C	2013	Avalanche	Body	Body Control Module (aux.)																																																										
C	2013	Avalanche	Body	Digital Radio Receiver																																																										
C	2013	Avalanche	Body	Driver Door Switch																																																										
C	2013	Avalanche	Body	HVAC Control Module Auto						V																																									V											
C	2013	Avalanche	Body	HVAC Control Module Manual						V																																																				
C	2013	Avalanche	Body	Instrument Panel Cluster																																																										
C	2013	Avalanche	Body	Memory Seat Module							V																																																			
C	2013	Avalanche	Body	Navigation Radio																																																										
C	2013	Avalanche	Body	Park Assist Module																																																										
C	2013	Avalanche	Body	Passenger Door Switch																																																										
C	2013	Avalanche	Body	Passenger Presence System																																																										
C	2013	Avalanche	Body	Radio																																																										
C	2013	Avalanche	Body	Rear Heated Seat Module																																																										
C	2013	Avalanche	Body	Rear HVAC/RSA																																																										
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																										
C	2013	Avalanche	Body	Theft Deterrent Module																																																										
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																										
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																										
C	2013	Captiva	Chassis	Electronic Brake Control Module																																																										
C	2013	Captiva	Chassis	Parking Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																										
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																										
C	2013	Captiva	Body	Auxiliary Body Control Module																																																										
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2013	Captiva	Body	Instrument Cluster																																																										
C	2013	Captiva	Body	Headlamp Control Module																																																										
C	2013	Captiva	Body	HVAC Control Module																																																										
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
C	2013	Captiva	Body	Theft Deterrent Module																																																										
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES					V																																																					
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES					V																																																					
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																						
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																										
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
C	2013	Cheyenne	Body	Amplifier (Bose)																																																										
C	2013	Cheyenne	Body	Body Control Module																																																										
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																										
C	2013	Cheyenne	Body	Digital Radio Receiver																																																										
C	2013	Cheyenne	Body	Driver Door Switch																																																										
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																										
C	2013	Cheyenne	Body	Park Assist Module																																																										
C	2013	Cheyenne	Body	Passenger Door Switch																																																										
C	2013	Cheyenne	Body	Passenger Presence System																																																										
C	2013	Cheyenne	Body	Rear Heated Seat Module																																																										
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																										
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
C	2013	Cheyenne	Body	Theft Deterrent Module																																																										
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed									V	V	V																																															
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2013	Suburban	Chassis	EBCM Under 8600 GVW					V																																																					
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW				V																																																						
C	2013	Suburban	Chassis	Electronic Suspension Control																																																										
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																									
C	2013	Suburban	Body	Amplifier (Bose)																																																									
C	2013	Suburban	Body	Assist Step Controller																																																									
C	2013	Suburban	Body	Body Control Module																																																									
C	2013	Suburban	Body	Body Control Module (aux.)																																																									
C	2013	Suburban	Body	Digital Radio Receiver																																																									
C	2013	Suburban	Body	Driver Door Switch																																																									
C	2013	Suburban	Body	HVAC Control Module Auto						V																																												V								
C	2013	Suburban	Body	HVAC Control Module Manual						V																																																				
C	2013	Suburban	Body	Instrument Panel Cluster																																																										
C	2013	Suburban	Body	Left Side Object Detection Module																																																										
C	2013	Suburban	Body	Lift Gate Module																																																										
C	2013	Suburban	Body	Memory Seat Module							V																																																			
C	2013	Suburban	Body	Navigation Radio																																																										
C	2013	Suburban	Body	Park Assist Module																																																										
C	2013	Suburban	Body	Passenger Door Switch																																																										
C	2013	Suburban	Body	Passenger Presence System																																																										
C	2013	Suburban	Body	Radio																																																										
C	2013	Suburban	Body	Rear Heated Seat Module																																																										
C	2013	Suburban	Body	Rear HVAC/RSA																																																										
C	2013	Suburban	Body	Right Side Object Detection Module																																																										
C	2013	Suburban	Body	Supplemental Inflatable Restraint																																																										
C	2013	Suburban	Body	Theft Deterrent Module																																																										
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																		V								
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																														
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																		V								
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																														
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																														
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual									V		V																																														
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module									V	V	V																																														
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V	V	V	V				V	V									
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								V	V	V															
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																							V					V													
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES					V																																																					
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																					
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES				V																																																						

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2013	Silverado	Chassis	Electronic Suspension Control																																																												
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
C	2013	Silverado	Body	Amplifier (Bose)																																																											
C	2013	Silverado	Body	Body Control Module																																																											
C	2013	Silverado	Body	Body Control Module (aux.)																																																											
C	2013	Silverado	Body	Digital Radio Receiver																																																											
C	2013	Silverado	Body	Driver Door Switch																																																											
C	2013	Silverado	Body	HVAC Control Module Auto						V																																									V											
C	2013	Silverado	Body	HVAC Control Module Manual						V																																																					
C	2013	Silverado	Body	Instrument Panel Cluster																																																											
C	2013	Silverado	Body	Memory Seat Module							V																																																			
C	2013	Silverado	Body	Navigation Radio																																																											
C	2013	Silverado	Body	Park Assist Module																																																											
C	2013	Silverado	Body	Passenger Door Switch																																																											
C	2013	Silverado	Body	Passenger Presence System																																																											
C	2013	Silverado	Body	Radio																																																											
C	2013	Silverado	Body	Rear Heated Seat Module																																																											
C	2013	Silverado	Body	Rear HVAC/RSA																																																											
C	2013	Silverado	Body	Supplemental Inflatable Restraint																																																											
C	2013	Silverado	Body	Theft Deterrent Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																V	V		V	V					
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																					V	V			
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																					V	V
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																											
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																											
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																											
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																											
C	2013	Silverado Hybrid	Body	Body Control Module																																																											
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																											
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																											
C	2013	Silverado Hybrid	Body	Driver Door Switch																																																											
C	2013	Silverado Hybrid	Body	Heated Seat Module																																																											
C	2013	Silverado Hybrid	Body	HVAC Control Module						V																																													V								
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																											
C	2013	Silverado Hybrid	Body	Navigation Radio																																																											
C	2013	Silverado Hybrid	Body	Park Assist Module																																																											
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																																											
C	2013	Silverado Hybrid	Body	Passenger Presence System																																																											
C	2013	Silverado Hybrid	Body	Radio																																																											
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																											
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																											
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																											
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2013	Tahoe	Chassis	Electronic Brake Control Module					V																																																						
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe	Body	Amplifier (Bose)																																																											
C	2013	Tahoe	Body	Assist Step Controller																																																											
C	2013	Tahoe	Body	Body Control Module																																																											
C	2013	Tahoe	Body	Body Control Module (aux.)																																																											
C	2013	Tahoe	Body	Digital Radio Receiver																																																											
C	2013	Tahoe	Body	Driver Door Switch																																																											
C	2013	Tahoe	Body	HVAC Control Module Auto						V																																										V											
C	2013	Tahoe	Body	HVAC Control Module Manual						V																																																					
C	2013	Tahoe	Body	Instrument Panel Cluster																																																											
C	2013	Tahoe	Body	Left Side Object Detection Module																																																											
C	2013	Tahoe	Body	Lift Gate Module																																																											
C	2013	Tahoe	Body	Memory Seat Module							V																																																				
C	2013	Tahoe	Body	Navigation Radio																																																											
C	2013	Tahoe	Body	Park Assist Module																																																											
C	2013	Tahoe	Body	Passenger Door Switch																																																											
C	2013	Tahoe	Body	Passenger Presence System																																																											
C	2013	Tahoe	Body	Radio																																																											
C	2013	Tahoe	Body	Rear Heated Seat Module																																																											
C	2013	Tahoe	Body	Rear HVAC/RSA																																																											
C	2013	Tahoe	Body	Right Side Object Detection Module																																																											
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																											
C	2013	Tahoe	Body	Theft Deterrent Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																V	V		V	V					
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																					V	V			
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																					V	V
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2013	Tahoe Hybrid	Body	Body Control Module																																																											
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																																												
C	2013	Tahoe Hybrid	Body	HVAC Control Module						V																																														V						
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2013	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2013	Tahoe Hybrid	Body	Navigation Radio																																																										
C	2013	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2013	Tahoe Hybrid	Body	Radio																																																										
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
C	2014	Captiva (3GN)	Body	Body Control Module																																																										
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Captiva (3GN)	Body	Passenger Presence Module																																																										
C	2014	Captiva (3GN)	Body	Instrument Cluster																																																										
C	2014	Captiva (3GN)	Body	Radio																																																										
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Captiva (3GN)	Body	HVAC Control Module																																																										
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																									V																																	
C	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																											
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																											
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																											
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Captiva (Other)	Body	Instrument Cluster																																																											
C	2014	Captiva (Other)	Body	Headlamp Control Module																																																											
C	2014	Captiva (Other)	Body	HVAC Control Module																																																											
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
C	2014	Captiva (Other)	Body	Theft Deterrent Module																																																											
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																											
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																											
C	2014	Cheyenne	Chassis	Power Steering Control Module																														V	V																											
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2014	Cheyenne	Body	Body Control Module																																																											
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Cheyenne	Body	Passenger Presence Module																																																											
C	2014	Cheyenne	Body	Instrument Cluster																																																											
C	2014	Cheyenne	Body	Radio Control																																																											
C	2014	Cheyenne	Body	HVAC Control																																																											
C	2014	Cheyenne	Body	Radio																																																											
C	2014	Cheyenne	Body	Amplifier																																																											
C	2014	Cheyenne	Body	Media Disc Player																																																											
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																											
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																											
C	2014	Cheyenne	Body	HVAC Control Module																																																											
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																											
C	2014	Cheyenne	Body	Parking Assist Control Module																																																											
C	2014	Cheyenne	Body	Frontview Camera Module																																																											
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																															
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
C	2014	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado	Chassis	Parking Brake Control Module																																																										
C	2014	Silverado	Chassis	Power Steering Control Module																														V	V																											
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2014	Silverado	Body	Body Control Module																																																										
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado	Body	Passenger Presence Module																																																										
C	2014	Silverado	Body	Instrument Cluster																																																										
C	2014	Silverado	Body	Radio Control																																																										
C	2014	Silverado	Body	HVAC Control																																																										
C	2014	Silverado	Body	Radio																																																										
C	2014	Silverado	Body	Amplifier																																																										
C	2014	Silverado	Body	Media Disc Player																																																										
C	2014	Silverado	Body	Human Machine Interface Control Module																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2014	Silverado	Body	Parking Assist Control Module																																																										
C	2014	Silverado	Body	Frontview Camera Module																																																										
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																							V																			
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																										
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																										
C	2014	Silverado HD	Chassis	Suspension Control Module																																																										
C	2014	Silverado HD	Body	Body Control Module																																																										
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Silverado HD	Body	Passenger Presence Module																																																										
C	2014	Silverado HD	Body	Instrument Cluster																																																										
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
C	2014	Silverado HD	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2014	Silverado HD	Body	Navigation Radio																																																										
C	2014	Silverado HD	Body	Uplevel Radio																																																										
C	2014	Silverado HD	Body	Amplifier																																																										
C	2014	Silverado HD	Body	Rear Audio Control Module																																																										
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																										
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																										
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Silverado HD	Body	Seat Memory Control Module																																																										
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																										
C	2014	Silverado HD	Body	Parking Assist Control Module																									V																																	
C	2014	Silverado HD	Body	Theft Deterrent Module																																																										
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																										
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																							V																																			
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																													V																													
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2014	Suburban	Chassis	Parking Brake Control Module																																																										
C	2014	Suburban	Chassis	Suspension Control Module																																																										
C	2014	Suburban	Body	Body Control Module																																																										
C	2014	Suburban	Body	Auxiliary Body Control Module																																																										
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2014	Suburban	Body	Passenger Presence Module																																																										
C	2014	Suburban	Body	Instrument Cluster																																																										
C	2014	Suburban	Body	Base Radio																																																										
C	2014	Suburban	Body	Navigation Radio																																																										
C	2014	Suburban	Body	Uplevel Radio																																																										
C	2014	Suburban	Body	Amplifier																																																										
C	2014	Suburban	Body	Rear Audio Control Module																																																										
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																										
C	2014	Suburban	Body	Personal Audio Link Control Module																																																										
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																										
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																										
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																										
C	2014	Suburban	Body	Liftgate Control Module																																																										
C	2014	Suburban	Body	Seat Memory Control Module																																																										
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2014	Suburban	Body	Assist Step Control Module																								V																																				
C	2014	Suburban	Body	Right Side Object Detection Control Module																																																											
C	2014	Suburban	Body	Left Side Object Detection Control Module																																																											
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																											
C	2014	Suburban	Body	Parking Assist Control Module																									V																																			
C	2014	Suburban	Body	Theft Deterrent Module																																																											
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																											
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																							V																																				
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																											
C	2014	Tahoe	Chassis	Suspension Control Module																																																											
C	2014	Tahoe	Body	Body Control Module																																																											
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																											
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Tahoe	Body	Passenger Presence Module																																																											
C	2014	Tahoe	Body	Instrument Cluster																																																											
C	2014	Tahoe	Body	Base Radio																																																											
C	2014	Tahoe	Body	Navigation Radio																																																											
C	2014	Tahoe	Body	Uplevel Radio																																																											
C	2014	Tahoe	Body	Amplifier																																																											
C	2014	Tahoe	Body	Rear Audio Control Module																																																											
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																											
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																											
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																											
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																											
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																											
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																											
C	2014	Tahoe	Body	Liftgate Control Module																																																											
C	2014	Tahoe	Body	Seat Memory Control Module																																																											
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																																											
C	2014	Tahoe	Body	Assist Step Control Module																								V																																			
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																																											
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																																											
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																											
C	2014	Tahoe	Body	Parking Assist Control Module																									V																																			
C	2014	Tahoe	Body	Theft Deterrent Module																																																											
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																											
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																											
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																											
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																											
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2015	Captiva (3GN)	Body	Body Control Module																																																												
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																																												
C	2015	Captiva (3GN)	Body	Instrument Cluster																																																												
C	2015	Captiva (3GN)	Body	Radio																																																												
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																												
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																												
C	2015	Captiva (3GN)	Body	HVAC Control Module																																																												
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																									V																																			
C	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																												
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																												
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																												
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																												
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																												
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																												
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																												
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																												
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																												
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																												
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																												
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Captiva (Other)	Body	Instrument Cluster																																																												
C	2015	Captiva (Other)	Body	Headlamp Control Module																																																												
C	2015	Captiva (Other)	Body	HVAC Control Module																																																												
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																												
C	2015	Captiva (Other)	Body	Theft Deterrent Module																																																												
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																												
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																													V																														
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																													V																														
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																										
C	2015	Cheyenne	Chassis	Power Steering Control Module																														V	V																												
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Cheyenne	Chassis	Suspension Control Module																																																										
C	2015	Cheyenne	Body	Body Control Module																																																										
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Cheyenne	Body	Passenger Presence Module																																																										
C	2015	Cheyenne	Body	Instrument Cluster																																																										
C	2015	Cheyenne	Body	Radio Controls																																																										
C	2015	Cheyenne	Body	HVAC Controls																																																										
C	2015	Cheyenne	Body	Radio																																																										
C	2015	Cheyenne	Body	Amplifier																																																										
C	2015	Cheyenne	Body	Media Disc Player																																																										
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																										
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
C	2015	Cheyenne	Body	HVAC Control Module																																																										
C	2015	Cheyenne	Body	Parking Assist Control Module																																																										
C	2015	Cheyenne	Body	Frontview Camera Module																																																										
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																								V																		
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																													V																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																													V																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
C	2015	Silverado	Chassis	Electronic Brake Control Module																																																										
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Silverado	Chassis	Power Steering Control Module																														V	V																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Silverado	Chassis	Suspension Control Module																																																												
C	2015	Silverado	Body	Body Control Module																																																											
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Silverado	Body	Passenger Presence Module																																																											
C	2015	Silverado	Body	Instrument Cluster																																																											
C	2015	Silverado	Body	Radio Controls																																																											
C	2015	Silverado	Body	HVAC Controls																																																											
C	2015	Silverado	Body	Radio																																																											
C	2015	Silverado	Body	Amplifier																																																											
C	2015	Silverado	Body	Media Disc Player																																																											
C	2015	Silverado	Body	Human Machine Interface Control Module																																																											
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																											
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
C	2015	Silverado	Body	Parking Assist Control Module																																																											
C	2015	Silverado	Body	Frontview Camera Module																																																											
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																											
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																							V					V																																
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																													V																														
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
C	2015	Suburban	Chassis	Electronic Brake Control Module																																																											
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																											
C	2015	Suburban	Chassis	Parking Brake Control Module																																																											
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																											
C	2015	Suburban	Chassis	Power Steering Control Module																														V	V																												
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2015	Suburban	Chassis	Suspension Control Module																																																											
C	2015	Suburban	Body	Body Control Module																																																											
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2015	Suburban	Body	Passenger Presence Module																																																											
C	2015	Suburban	Body	Instrument Cluster																																																											
C	2015	Suburban	Body	Radio Controls																																																											
C	2015	Suburban	Body	HVAC Controls																																																											
C	2015	Suburban	Body	Radio																																																											
C	2015	Suburban	Body	Amplifier																																																											
C	2015	Suburban	Body	Media Disc Player																																																											
C	2015	Suburban	Body	Human Machine Interface Control Module																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																											
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2015	Suburban	Body	HVAC Control Module																																																											
C	2015	Suburban	Body	Liftgate Control Module																																																											
C	2015	Suburban	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2015	Suburban	Body	Assist Step Control Module																																																										
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																										
C	2015	Suburban	Body	Parking Assist Control Module																																																										
C	2015	Suburban	Body	Frontview Camera Module																																																										
C	2015	Suburban	Body	Steering Column Lock Control Module																																																										
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																															
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																										
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																							V					V																														
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																													V																													
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																										
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																										
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																										
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																																										
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																										
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																										
C	2015	Tahoe	Chassis	Power Steering Control Module																														V	V																											
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2015	Tahoe	Chassis	Suspension Control Module																																																										
C	2015	Tahoe	Body	Body Control Module																																																										
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2015	Tahoe	Body	Passenger Presence Module																																																										
C	2015	Tahoe	Body	Instrument Cluster																																																										
C	2015	Tahoe	Body	Radio Controls																																																										
C	2015	Tahoe	Body	HVAC Controls																																																										
C	2015	Tahoe	Body	Radio																																																										
C	2015	Tahoe	Body	Amplifier																																																										
C	2015	Tahoe	Body	Media Disc Player																																																										
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																										
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																										
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2015	Tahoe	Body	HVAC Control Module																																																										
C	2015	Tahoe	Body	Liftgate Control Module																																																										
C	2015	Tahoe	Body	Keyless Entry Control Module																																																										
C	2015	Tahoe	Body	Assist Step Control Module																																																										
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																										
C	2015	Tahoe	Body	Parking Assist Control Module																																																										
C	2015	Tahoe	Body	Frontview Camera Module																																																										
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																										
C	2015	Tahoe	Body	Battery Energy Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																												
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																												
C	2016	Captiva (3GN)	Body	Body Control Module																																																												
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Captiva (3GN)	Body	Instrument Cluster																																																												
C	2016	Captiva (3GN)	Body	Radio																																																												
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																												
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																												
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																												
C	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																												
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																												
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																												
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																												
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																												
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																												
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																												
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																												
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																												
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																												
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																												
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																												
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																												
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Captiva (Other)	Body	Instrument Cluster																																																												
C	2016	Captiva (Other)	Body	Headlamp Control Module																																																												
C	2016	Captiva (Other)	Body	Radio																																																												
C	2016	Captiva (Other)	Body	HVAC Control Module																																																												
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																												
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																												
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																												
C	2016	Captiva (Other)	Body	Theft Deterrent Module																																																												
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																													V																															
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																															
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																															
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																											
C	2016	Cheyenne	Chassis	Power Steering Control Module																														V	V																													
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2016	Cheyenne	Chassis	Suspension Control Module																																																											
C	2016	Cheyenne	Body	Body Control Module																																																											
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Cheyenne	Body	Passenger Presence Module																																																											
C	2016	Cheyenne	Body	Instrument Cluster																																																											
C	2016	Cheyenne	Body	Radio Controls																																																											
C	2016	Cheyenne	Body	HVAC Controls																																																											
C	2016	Cheyenne	Body	Radio																																																											
C	2016	Cheyenne	Body	Amplifier																																																											
C	2016	Cheyenne	Body	Media Disc Player																																																											
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																											
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																											
C	2016	Cheyenne	Body	HVAC Control Module																																																											
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																											
C	2016	Cheyenne	Body	Parking Assist Control Module																																																											
C	2016	Cheyenne	Body	Frontview Camera Module																																																											
C	2016	Cheyenne	Body	Frontview Camera Module																																																											
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																											
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																											
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																											
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																											
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																								V																			
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																													V																														
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
C	2016	Silverado	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2016	Silverado	Chassis	Power Steering Control Module																																																												
C	2016	Silverado	Chassis	Power Steering Control Module																														V	V																													
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2016	Silverado	Chassis	Suspension Control Module																																																												
C	2016	Silverado	Body	Body Control Module																																																												
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Silverado	Body	Passenger Presence Module																																																												
C	2016	Silverado	Body	Instrument Cluster																																																												
C	2016	Silverado	Body	Radio Controls																																																												
C	2016	Silverado	Body	HVAC Controls																																																												
C	2016	Silverado	Body	Radio (IO3)																																																												
C	2016	Silverado	Body	Radio (IOB)																																																												
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																												
C	2016	Silverado	Body	Amplifier																																																												
C	2016	Silverado	Body	Media Disc Player																																																												
C	2016	Silverado	Body	Human Machine Interface Control Module																																																												
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																												
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																												
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																												
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																												
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																												
C	2016	Silverado	Body	Parking Assist Control Module																																																												
C	2016	Silverado	Body	Frontview Camera Module																																																												
C	2016	Silverado	Body	Frontview Camera Module																																																												
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
C	2016	Suburban	Chassis	Electronic Brake Control Module																																																												
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																												
C	2016	Suburban	Chassis	Parking Brake Control Module																																																												
C	2016	Suburban	Chassis	Power Steering Control Module																														V	V																													
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2016	Suburban	Chassis	Suspension Control Module																																																												
C	2016	Suburban	Body	Body Control Module																																																												
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Suburban	Body	Passenger Presence Module																																																												
C	2016	Suburban	Body	Instrument Cluster																																																												
C	2016	Suburban	Body	Radio Controls																																																												
C	2016	Suburban	Body	HVAC Controls																																																												
C	2016	Suburban	Body	Radio																																																												
C	2016	Suburban	Body	Amplifier																																																												
C	2016	Suburban	Body	Media Disc Player																																																												
C	2016	Suburban	Body	Human Machine Interface Control Module																																																												
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																																												
C	2016	Suburban	Body	HVAC Control Module																																																												
C	2016	Suburban	Body	Liftgate Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																								
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																								
C	2016	Suburban	Body	Keyless Entry Control Module																																																								
C	2016	Suburban	Body	Assist Step Control Module																																																								
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																								
C	2016	Suburban	Body	Parking Assist Control Module																																																								
C	2016	Suburban	Body	Frontview Camera Module																																																								
C	2016	Suburban	Body	Steering Column Lock Control Module																																																								
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																											
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																											
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																																								
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																								
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																								
C	2016	Tahoe	Chassis	Power Steering Control Module																														V	V																									
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																								
C	2016	Tahoe	Chassis	Suspension Control Module																																																								
C	2016	Tahoe	Body	Body Control Module																																																								
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
C	2016	Tahoe	Body	Passenger Presence Module																																																								
C	2016	Tahoe	Body	Instrument Cluster																																																								
C	2016	Tahoe	Body	Radio Controls																																																								
C	2016	Tahoe	Body	HVAC Controls																																																								
C	2016	Tahoe	Body	Radio																																																								
C	2016	Tahoe	Body	Amplifier																																																								
C	2016	Tahoe	Body	Media Disc Player																																																								
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																								
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																								
C	2016	Tahoe	Body	HVAC Control Module																																																								
C	2016	Tahoe	Body	Liftgate Control Module																																																								
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																								
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																								
C	2016	Tahoe	Body	Keyless Entry Control Module																																																								
C	2016	Tahoe	Body	Assist Step Control Module																																																								
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																								
C	2016	Tahoe	Body	Parking Assist Control Module																																																								
C	2016	Tahoe	Body	Frontview Camera Module																																																								
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																								
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																															V	V																								
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																															V	V																								
E	2004	ALL	Chassis	Electronic Brake Control Module																																																								
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																															V	V																								
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																															V	V																								
E	2006	ALL	Chassis	Electronic Brake Control Module																																	V																							
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																															V	V																								
E	2007	ALL	Chassis	Electronic Brake Control Module																																	V																							
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																												
G	2004	Express/Savana	Chassis	VSES																																																												
G	2004	Express/Savana	Body	Body Control Module																																																												
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																												
G	2004	Express/Savana	Body	OnStar																																																												
G	2004	Express/Savana	Body	Base Radio																																																												
G	2004	Express/Savana	Body	Uplevel Radio																																																												
G	2004	Express/Savana	Body	Remote Function Actuation																																																												
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint		V																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
G	2004	Express Access/Savana Pro	Chassis	VSES																																																												
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
G	2004	Express Access/Savana Pro	Body	OnStar																																																												
G	2004	Express Access/Savana Pro	Body	Base Radio																																																												
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																												
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint		V																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2005	Express/Savana	Chassis	VSES																																																										
G	2005	Express/Savana	Body	Body Control Module																																																										
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2005	Express/Savana	Body	Base Radio																																																										
G	2005	Express/Savana	Body	Uplevel Radio																																																										
G	2005	Express/Savana	Body	Remote Function Actuation																																																										
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint		V																																																								
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2005	Express Access/Savana Pro	Chassis	VSES																																																										
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2005	Express Access/Savana Pro	Body	Base Radio																																																										
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint		V																																																								
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																							
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																							
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																							
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																							
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																							V				V													
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																							
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																							
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								V	V	V													
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																							
G	2006	Express/Savana	Chassis	VSES																																																							
G	2006	Express/Savana	Body	Body Control Module																																																							
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																							
G	2006	Express/Savana	Body	Passenger Presence System																																																							
G	2006	Express/Savana	Body	Base Radio																																																							
G	2006	Express/Savana	Body	Uplevel Radio																																																							
G	2006	Express/Savana	Body	Remote Function Actuation																																																							
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint		V																																																						
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																							
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																							
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																							
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																							
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																							
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																							
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																							
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																							
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																							
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																							
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																							
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																							
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																							
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																							V				V													
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																							
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																							
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								V	V	V													
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																							
G	2006	Express Access/Savana Pro	Chassis	VSES																																																							
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																							
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																							
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																							
G	2006	Express Access/Savana Pro	Body	Base Radio																																																							
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																							
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																							
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint		V																																																					

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																							V	V	V	V	V															
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								V	V	V																
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																								V	V	V							V									
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express/Savana	Body	Body Control Module																																																										
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2007	Express/Savana	Body	Passenger Presence System																																																										
G	2007	Express/Savana	Body	Base Radio																																																										
G	2007	Express/Savana	Body	Uplevel Radio																																																										
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																							V	V	V	V	V														
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								V	V	V															
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																								V	V	V								V							
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2007	Express Access/Savana Pro	Body	Radio																																																									
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V														
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V														
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V									
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V								V							
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																					
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2008	Express/Savana	Body	Body Control Module																																																									
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2008	Express/Savana	Body	Passenger Presence System																																																									
G	2008	Express/Savana	Body	Radio																																																								
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2008	Express/Savana	Body	Rollover Sensor																																																									
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2008	Express/Savana	Body	Theft Deterrent Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V														
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V														
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																					
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2008	Express Access/Savana Pro	Body	Radio																																																										
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V														
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V														
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V								
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																						
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2009	Express/Savana	Body	Body Control Module																																																										
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2009	Express/Savana	Body	Passenger Presence System																																																										
G	2009	Express/Savana	Body	Radio																																																										
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express/Savana	Body	Rollover Sensor																																																										
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2009	Express/Savana	Body	Theft Deterrent Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V														
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V														
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V								V								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																							
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2009	Express Access/Savana Pro	Body	Radio																																																										
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																													V												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																													V												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V																
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V								V							
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																							
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2010	Express/Savana	Body	Body Control Module																																																										
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2010	Express/Savana	Body	Passenger Presence System																																																										
G	2010	Express/Savana	Body	Radio																																																										
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2010	Express/Savana	Body	Rollover Sensor																																																										
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2010	Express/Savana	Body	Theft Deterrent Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																													V												
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																													V												
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V																
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V									
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																					
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2010	Express Access/Savana Pro	Body	Radio																																																									
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																													V													
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																														
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																														
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																													V													
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																														
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V									
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V															
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																						
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2011	Express/Savana	Body	Body Control Module																																																										
G	2011	Express/Savana	Body	Digital Radio Receiver																																																										
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2011	Express/Savana	Body	Passenger Presence System																																																										
G	2011	Express/Savana	Body	Radio																																																									
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2011	Express/Savana	Body	Rollover Sensor																																																										
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2011	Express/Savana	Body	Theft Deterrent Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																													V													
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																														
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																													V													
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																														
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V							
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V												
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																					
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																	
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																					
G	2011	Express Access/Savana Pro	Body	Body Control Module																																																					
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																					
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																					
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																					
G	2011	Express Access/Savana Pro	Body	Radio																																																					
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																					
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																					
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																					
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																					
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																					
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V										
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																											
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																					
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																										
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																					
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V										
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																										
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																					
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																					
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																					
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																					
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V							
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V												
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																					
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																	
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																					
G	2012	Express/Savana	Body	Body Control Module																																																					
G	2012	Express/Savana	Body	Digital Radio Receiver																																																					
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																					
G	2012	Express/Savana	Body	Passenger Presence System																																																					
G	2012	Express/Savana	Body	Radio																																																					
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																					
G	2012	Express/Savana	Body	Rollover Sensor																																																					
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																					
G	2012	Express/Savana	Body	Theft Deterrent Module																																																					
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																					
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V										
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																											
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																					
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																										
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																					
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V										
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																										
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																					
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																					
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																					

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V								
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V														
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																				
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2012	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2012	Express Access/Savana Pro	Body	Radio																																																								
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V													
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																														
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																														
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V													
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																														
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V														
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																				
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2013	Express/Savana	Body	Body Control Module																																																								
G	2013	Express/Savana	Body	Digital Radio Receiver																																																								
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2013	Express/Savana	Body	Navigation Radio																																																								
G	2013	Express/Savana	Body	Park Assist Module																																																								
G	2013	Express/Savana	Body	Passenger Presence System																																																								
G	2013	Express/Savana	Body	Radio																																																								
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2013	Express/Savana	Body	Rollover Sensor																																																								
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2013	Express/Savana	Body	Theft Deterrent Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V													
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																														
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																														
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V													
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																														

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V			V	V									
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V														
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																						
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2013	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2013	Express Access/Savana Pro	Body	Radio																																																										
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																								V																		
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2014	Express	Chassis	Electronic Brake Control Module																																																										
G	2014	Express	Body	Body Control Module																																																										
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2014	Express	Body	Passenger Presence Module																																																										
G	2014	Express	Body	Rollover Sensor Module																																																										
G	2014	Express	Body	Instrument Cluster																																																										
G	2014	Express	Body	Chime Alarm Control Module																																																										
G	2014	Express	Body	Base Radio																																																										
G	2014	Express	Body	Navigation Radio																																																										
G	2014	Express	Body	Uplevel Radio																																																										
G	2014	Express	Body	Digital Radio Receiver Control Module																																																										
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
G	2014	Express	Body	Auxiliary Heater Control Module																																																										
G	2014	Express	Body	Remote Control Door Lock Receiver																																																										
G	2014	Express	Body	Parking Assist Control Module																																																										
G	2014	Express	Body	Theft Deterrent Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																											
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																											
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																											
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																											
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																											
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																									V																		
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
G	2014	Savana	Chassis	Electronic Brake Control Module																																																											
G	2014	Savana	Body	Body Control Module																																																										
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
G	2014	Savana	Body	Passenger Presence Module																																																											
G	2014	Savana	Body	Rollover Sensor Module																																																											
G	2014	Savana	Body	Instrument Cluster																																																											
G	2014	Savana	Body	Chime Alarm Control Module																																																											
G	2014	Savana	Body	Base Radio																																																										
G	2014	Savana	Body	Navigation Radio																																																										
G	2014	Savana	Body	Uplevel Radio																																																										
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																											
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											
G	2014	Savana	Body	Auxiliary Heater Control Module																																																											
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																											
G	2014	Savana	Body	Parking Assist Control Module																																																											
G	2014	Savana	Body	Theft Deterrent Module																																																											
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																									V																		
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
G	2015	Express	Chassis	Electronic Brake Control Module																																																											
G	2015	Express	Body	Body Control Module																																																										
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
G	2015	Express	Body	Rollover Sensor Module																																																											
G	2015	Express	Body	Instrument Cluster																																																										
G	2015	Express	Body	Digital Radio Receiver Control Module																																																											
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																											
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																											
G	2015	Express	Body	Auxiliary Heater Control Module																																																											
G	2015	Express	Body	Remote Control Door Lock Receiver																																																											
G	2015	Express	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2015	Express	Body	Theft Deterrent Module																																																											
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																									V																		
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
G	2015	Savana	Chassis	Electronic Brake Control Module																																																												
G	2015	Savana	Body	Body Control Module																																																											
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2015	Savana	Body	Rollover Sensor Module																																																												
G	2015	Savana	Body	Instrument Cluster																																																												
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																												
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																												
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																												
G	2015	Savana	Body	Auxiliary Heater Control Module																																																												
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																												
G	2015	Savana	Body	Parking Assist Control Module																																																											
G	2015	Savana	Body	Theft Deterrent Module																																																												
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																									V																		
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
G	2016	Express	Chassis	Electronic Brake Control Module																																																												
G	2016	Express	Body	Body Control Module																																																											
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2016	Express	Body	Instrument Cluster																																																											
G	2016	Express	Body	Chime Alarm Control Module																																																												
G	2016	Express	Body	Base Radio																																																											
G	2016	Express	Body	Navigation Radio																																																											
G	2016	Express	Body	Uplevel Radio																																																											
G	2016	Express	Body	Digital Radio Receiver Control Module																																																												
G	2016	Express	Body	Telematics Communication Interface Control Module																																																												
G	2016	Express	Body	Auxiliary Heater Control Module																																																												
G	2016	Express	Body	Remote Control Door Lock Receiver																																																												
G	2016	Express	Body	Parking Assist Control Module																																																											
G	2016	Express	Body	Theft Deterrent Module																																																											
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								V																
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																							
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																							
G	2016	Savana	Chassis	Electronic Brake Control Module																																																							
G	2016	Savana	Body	Body Control Module																																																						
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
G	2016	Savana	Body	Instrument Cluster																																																						
G	2016	Savana	Body	Chime Alarm Control Module																																																						
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																						
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																						
G	2016	Savana	Body	Auxiliary Heater Control Module																																																						
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																						
G	2016	Savana	Body	Parking Assist Control Module																																																						
G	2016	Savana	Body	Theft Deterrent Module																																																						
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																						
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																						
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																						
H	2004	Express/Savana	Chassis	VSES																																																						
H	2004	Express/Savana	Body	Body Control Module																																																						
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																						
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																						
H	2004	Express/Savana	Body	OnStar																																																						
H	2004	Express/Savana	Body	Base Radio																																																						
H	2004	Express/Savana	Body	Uplevel Radio																																																						
H	2004	Express/Savana	Body	Remote Function Actuation																																																						
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint		V																																																					
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																						
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																						
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																						
H	2004	Express Access/Savana Pro	Chassis	VSES																																																						
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																						
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																						
H	2004	Express Access/Savana Pro	Body	OnStar																																																						
H	2004	Express Access/Savana Pro	Body	Base Radio																																																						
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																						
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																						
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint		V																																																				
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																						
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																						
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																						
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																						
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																						
H	2005	Express/Savana	Chassis	VSES																																																					
H	2005	Express/Savana	Body	Body Control Module																																																					
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																						
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																						
H	2005	Express/Savana	Body	Base Radio																																																						
H	2005	Express/Savana	Body	Uplevel Radio																																																						
H	2005	Express/Savana	Body	Remote Function Actuation																																																						
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint		V																																																				

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2005	Express Access/Savana Pro	Chassis	VSES																																																												
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2005	Express Access/Savana Pro	Body	Base Radio																																																												
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint		V																																																										
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																												
H	2006	Express/Savana	Chassis	VSES																																																												
H	2006	Express/Savana	Body	Body Control Module																																																												
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																												
H	2006	Express/Savana	Body	Passenger Presence System																																																												
H	2006	Express/Savana	Body	Base Radio																																																												
H	2006	Express/Savana	Body	Uplevel Radio																																																												
H	2006	Express/Savana	Body	Remote Function Actuation																																																												
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint		V																																																									
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2006	Express Access/Savana Pro	Chassis	VSES																																																												
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2006	Express Access/Savana Pro	Body	Base Radio																																																												
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint		V																																																									
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express/Savana	Body	Body Control Module																																																										
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2007	Express/Savana	Body	Passenger Presence System																																																										
H	2007	Express/Savana	Body	Base Radio																																																										
H	2007	Express/Savana	Body	Uplevel Radio																																																										
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2007	Express Access/Savana Pro	Body	Base Radio																																																										
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																															V											
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																															V											
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																						
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express/Savana	Body	Body Control Module																																																										
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2008	Express/Savana	Body	Passenger Presence System																																																										
H	2008	Express/Savana	Body	Radio																																																										
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express/Savana	Body	Rollover Sensor																																																										
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express/Savana	Body	Theft Deterrent Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																															V											
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																													V													
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																							
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																											
H	2008	Express Access/Savana Pro	Body	Radio																																																											
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																											
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																													V													
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																													V													
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																							
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2009	Express/Savana	Body	Body Control Module																																																											
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2009	Express/Savana	Body	Passenger Presence System																																																											
H	2009	Express/Savana	Body	Radio																																																											
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
H	2009	Express/Savana	Body	Rollover Sensor																																																											
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2009	Express/Savana	Body	Theft Deterrent Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																													V													
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																													V													
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																							
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																											
H	2009	Express Access/Savana Pro	Body	Radio																																																											
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																						
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express/Savana	Body	Body Control Module																																																										
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2010	Express/Savana	Body	Passenger Presence System																																																										
H	2010	Express/Savana	Body	Radio																																																										
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express/Savana	Body	Rollover Sensor																																																										
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express/Savana	Body	Theft Deterrent Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																						
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2010	Express Access/Savana Pro	Body	Radio																																																										
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																						
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2011	Express/Savana	Body	Body Control Module																																																										
H	2011	Express/Savana	Body	Digital Radio Receiver																																																										
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2011	Express/Savana	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2011	Express/Savana	Body	Radio																																																										
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2011	Express/Savana	Body	Rollover Sensor																																																										
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2011	Express/Savana	Body	Theft Deterrent Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																														V												
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																						
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2011	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2011	Express Access/Savana Pro	Body	Radio																																																										
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																														V												
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																						
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2012	Express/Savana	Body	Body Control Module																																																										
H	2012	Express/Savana	Body	Digital Radio Receiver																																																										
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2012	Express/Savana	Body	Passenger Presence System																																																										
H	2012	Express/Savana	Body	Radio																																																										
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2012	Express/Savana	Body	Rollover Sensor																																																										
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2012	Express/Savana	Body	Theft Deterrent Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																															V											
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																							
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2012	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2012	Express Access/Savana Pro	Body	Radio																																																										
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																							
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2013	Express/Savana	Body	Body Control Module																																																										
H	2013	Express/Savana	Body	Digital Radio Receiver																																																										
H	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2013	Express/Savana	Body	Navigation Radio																																																										
H	2013	Express/Savana	Body	Park Assist Module																																																										
H	2013	Express/Savana	Body	Passenger Presence System																																																										
H	2013	Express/Savana	Body	Radio																																																										
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2013	Express/Savana	Body	Rollover Sensor																																																										
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2013	Express/Savana	Body	Theft Deterrent Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																							
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2013	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																																								
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2013	Express Access/Savana Pro	Body	Radio																																																								
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																								
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																								
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																								
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																								
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																								
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																								
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																																								
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																								V																	
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
H	2014	Express	Chassis	Electronic Brake Control Module																																																								
H	2014	Express	Body	Body Control Module																																																								
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
H	2014	Express	Body	Passenger Presence Module																																																								
H	2014	Express	Body	Rollover Sensor Module																																																								
H	2014	Express	Body	Instrument Cluster																																																								
H	2014	Express	Body	Chime Alarm Control Module																																																								
H	2014	Express	Body	Base Radio																																																								
H	2014	Express	Body	Navigation Radio																																																								
H	2014	Express	Body	Uplevel Radio																																																								
H	2014	Express	Body	Digital Radio Receiver Control Module																																																								
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																								
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																								
H	2014	Express	Body	Auxiliary Heater Control Module																																																								
H	2014	Express	Body	Remote Control Door Lock Receiver																																																								
H	2014	Express	Body	Parking Assist Control Module																																																								
H	2014	Express	Body	Theft Deterrent Module																																																								
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																								
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																								
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																								
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																								
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																								
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																								
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																								
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								V																	
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
H	2014	Savana	Chassis	Electronic Brake Control Module																																																										
H	2014	Savana	Body	Body Control Module																																																									
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2014	Savana	Body	Passenger Presence Module																																																										
H	2014	Savana	Body	Rollover Sensor Module																																																										
H	2014	Savana	Body	Instrument Cluster																																																										
H	2014	Savana	Body	Chime Alarm Control Module																																																										
H	2014	Savana	Body	Base Radio																																																										
H	2014	Savana	Body	Navigation Radio																																																										
H	2014	Savana	Body	Uplevel Radio																																																										
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2014	Savana	Body	Auxiliary Heater Control Module																																																										
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2014	Savana	Body	Parking Assist Control Module																																																										
H	2014	Savana	Body	Theft Deterrent Module																																																										
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																									V																	
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2015	Express	Chassis	Electronic Brake Control Module																																																										
H	2015	Express	Body	Body Control Module																																																										
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2015	Express	Body	Rollover Sensor Module																																																										
H	2015	Express	Body	Instrument Cluster																																																										
H	2015	Express	Body	Digital Radio Receiver Control Module																																																										
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2015	Express	Body	Auxiliary Heater Control Module																																																										
H	2015	Express	Body	Remote Control Door Lock Receiver																																																										
H	2015	Express	Body	Parking Assist Control Module																																																										
H	2015	Express	Body	Theft Deterrent Module																																																										
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																									V																	
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2015	Savana	Chassis	Electronic Brake Control Module																																																										
H	2015	Savana	Body	Body Control Module																																																										
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2015	Savana	Body	Rollover Sensor Module																																																										
H	2015	Savana	Body	Instrument Cluster																																																										
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
H	2015	Savana	Body	Auxiliary Heater Control Module																																																										
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2015	Savana	Body	Parking Assist Control Module																																																										
H	2015	Savana	Body	Theft Deterrent Module																																																										
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																								V																		
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2016	Express	Chassis	Electronic Brake Control Module																																																										
H	2016	Express	Body	Body Control Module																																																										
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Express	Body	Instrument Cluster																																																										
H	2016	Express	Body	Chime Alarm Control Module																																																										
H	2016	Express	Body	Base Radio																																																										
H	2016	Express	Body	Navigation Radio																																																										
H	2016	Express	Body	Uplevel Radio																																																										
H	2016	Express	Body	Digital Radio Receiver Control Module																																																										
H	2016	Express	Body	Telematics Communication Interface Control Module																																																										
H	2016	Express	Body	Auxiliary Heater Control Module																																																										
H	2016	Express	Body	Remote Control Door Lock Receiver																																																										
H	2016	Express	Body	Parking Assist Control Module																																																										
H	2016	Express	Body	Theft Deterrent Module																																																										
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								V																		
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
H	2016	Savana	Chassis	Electronic Brake Control Module																																																										
H	2016	Savana	Body	Body Control Module																																																										
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
H	2016	Savana	Body	Instrument Cluster																																																										
H	2016	Savana	Body	Chime Alarm Control Module																																																										
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
H	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
H	2016	Savana	Body	Auxiliary Heater Control Module																																																										
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
H	2016	Savana	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2016	Savana	Body	Theft Deterrent Module																																																								
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																															V	V																								
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																															V	V																								
J	2004	ALL	Chassis	Electronic Brake Control Module																																																								
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																															V	V																								
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																															V	V																								
J	2007	ALL	Chassis	Electronic Brake Control Module																																	V																							
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																								
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																								
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																																								
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																								
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																								
J	2013	Tracker	Chassis	Power Steering Control Module																																																								
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																								
J	2013	Tracker	Body	Body Control Module																																																								
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
J	2013	Tracker	Body	Passenger Presence Module																																																								
J	2013	Tracker	Body	Instrument Cluster																																																								
J	2013	Tracker	Body	Radio																																																								
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																																								
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																																								
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																								
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																																								
J	2013	Tracker	Body	Front Seat Heating Control Module																																																								
J	2013	Tracker	Body	Parking Assist Control Module																																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
J	2013	Tracker	Body	Frontview Camera Module																																																												
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																												
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																												
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																												
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
J	2013	Trax	Chassis	Electronic Brake Control Module																																																												
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2013	Trax	Chassis	Power Steering Control Module																																																												
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2013	Trax	Body	Body Control Module																																																											
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2013	Trax	Body	Passenger Presence Module																																																												
J	2013	Trax	Body	Instrument Cluster																																																											
J	2013	Trax	Body	Radio																																																											
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																												
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
J	2013	Trax	Body	Front Seat Heating Control Module																																																												
J	2013	Trax	Body	Parking Assist Control Module																																																												
J	2013	Trax	Body	Frontview Camera Module																																																												
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																											
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																											
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																											
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																											
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																											
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																											
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																											
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																																											
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																											
J	2014	Tracker	Chassis	Power Steering Control Module																																																											
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2014	Tracker	Body	Body Control Module																																																										
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2014	Tracker	Body	Passenger Presence Module																																																											
J	2014	Tracker	Body	Instrument Cluster																																																											
J	2014	Tracker	Body	Radio																																																										
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																																											
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																																											
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																																											
J	2014	Tracker	Body	Front Seat Heating Control Module																																																											
J	2014	Tracker	Body	Parking Assist Control Module																																																											
J	2014	Tracker	Body	Frontview Camera Module																																																											
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																											
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																											
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																											
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																											
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																												
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																											
J	2014	Trax	Chassis	Electronic Brake Control Module																																																											
J	2014	Trax	Chassis	Power Steering Control Module																																																											
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2014	Trax	Body	Body Control Module																																																										
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2014	Trax	Body	Passenger Presence Module																																																											
J	2014	Trax	Body	Instrument Cluster																																																										
J	2014	Trax	Body	Radio																																																										
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2014	Trax	Body	Front Seat Heating Control Module																																																										
J	2014	Trax	Body	Parking Assist Control Module																																																										
J	2014	Trax	Body	Frontview Camera Module																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2015	Tracker	Chassis	Power Steering Control Module																																																										
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Tracker	Body	Body Control Module																																																										
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Tracker	Body	Instrument Cluster																																																										
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																																										
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Tracker	Body	Front Seat Heating Control Module																																																										
J	2015	Tracker	Body	Parking Assist Control Module																																																										
J	2015	Tracker	Body	Frontview Camera Module																																																										
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2015	Trax	Powertrain	Chassis Control Module																																																										
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Trax	Chassis	Electronic Brake Control Module																																																										
J	2015	Trax	Chassis	Power Steering Control Module																																																										
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Trax	Body	Body Control Module																																																										
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Trax	Body	Passenger Presence Module																																																										
J	2015	Trax	Body	Instrument Cluster																																																										
J	2015	Trax	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																										
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Trax	Body	Seat Memory Control Module																																																										
J	2015	Trax	Body	Front Seat Heating Control Module																																																										
J	2015	Trax	Body	Right Side Object Detection Control Module																																																										
J	2015	Trax	Body	Left Side Object Detection Control Module																																																										
J	2015	Trax	Body	Parking Assist Control Module																																																										
J	2015	Trax	Body	Frontview Camera Module																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																										
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																										
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																										
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2016	Tracker	Chassis	Power Steering Control Module																																																										
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2016	Tracker	Body	Body Control Module																																																										
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2016	Tracker	Body	Instrument Cluster																																																										
J	2016	Tracker	Body	Trailer Interface Control Module																																																										
J	2016	Tracker	Body	Radio																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																																										
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2016	Tracker	Body	Front Seat Heating Control Module																																																										
J	2016	Tracker	Body	Parking Assist Control Module																																																										
J	2016	Tracker	Body	Frontview Camera Module																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																									
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																									
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																									
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																									
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																									
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																									
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																									
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																									
J	2016	Trax	Powertrain	Chassis Control Module																																																									
J	2016	Trax	Chassis	Electronic Brake Control Module																																																									
J	2016	Trax	Chassis	Power Steering Control Module																																																									
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																									
J	2016	Trax	Body	Body Control Module																																																									
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
J	2016	Trax	Body	Passenger Presence Module																																																									
J	2016	Trax	Body	Instrument Cluster																																																									
J	2016	Trax	Body	Trailer Interface Control Module																																																									
J	2016	Trax	Body	Radio																																																									
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																									
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																									
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																									
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																									
J	2016	Trax	Body	Seat Memory Control Module																																																									
J	2016	Trax	Body	Front Seat Heating Control Module																																																									
J	2016	Trax	Body	Right Side Object Detection Control Module																																																									
J	2016	Trax	Body	Left Side Object Detection Control Module																																																									
J	2016	Trax	Body	Parking Assist Control Module																																																									
J	2016	Trax	Body	Frontview Camera Module																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																			V	V																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																					V																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																						V																						
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																							V																					
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																						V		V																					
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																							V																					
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																							V																					
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
K	2004	ALL	Chassis	ESC																																																											
K	2004	ALL	Chassis	Rear Wheel Steering																																																												
K	2004	ALL	Chassis	Tire Pressure Monitor																																																												
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																												
K	2004	ALL	Chassis	VSES																																																											
K	2004	ALL	Body	Amplifier (Bose)																																																												
K	2004	ALL	Body	Body Control Module																																																												
K	2004	ALL	Body	CD Changer																																																												
K	2004	ALL	Body	Chime																																																												
K	2004	ALL	Body	Driver Door Module																																																												
K	2004	ALL	Body	Driver Seat Module																																																												
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2004	ALL	Body	Instrument Panel Cluster																																																												
K	2004	ALL	Body	OnStar																																																											
K	2004	ALL	Body	Passenger Door Module																																																											
K	2004	ALL	Body	Passenger Presence System																																																												
K	2004	ALL	Body	Radio Base																																																												
K	2004	ALL	Body	Radio Uplevel																																																												
K	2004	ALL	Body	Radio Navigation																																																												
K	2004	ALL	Body	Rear Aux. Climate Module	V																																																											
K	2004	ALL	Body	Rear HVAC																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2004	ALL	Body	Rear Seat Audio																																																									
K	2004	ALL	Body	Rear Seat Entertainment																																																									
K	2004	ALL	Body	Supplemental Inflatable Restraint		V																																																							
K	2004	ALL	Body	Vehicle Theft Deterrent																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																		V	V																						
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																						V		V																		
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																							V																		
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																							V																		
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																								
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																								
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
K	2005	ALL	Chassis	ESC																																																								
K	2005	ALL	Chassis	Rear Wheel Steering																																																								
K	2005	ALL	Chassis	Tire Pressure Monitor																																																								
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																								
K	2005	ALL	Chassis	VSES																																																								
K	2005	ALL	Body	Amplifier (Bose)																																																								
K	2005	ALL	Body	Body Control Module																																																								
K	2005	ALL	Body	CD Changer																																																								
K	2005	ALL	Body	Chime																																																								
K	2005	ALL	Body	Disc Player and Video Display																																																								
K	2005	ALL	Body	Driver Door Module																																																								
K	2005	ALL	Body	Driver Seat Module																																																								
K	2005	ALL	Body	Generator Battery Control Module																																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																								
K	2005	ALL	Body	Instrument Panel Cluster																																																								
K	2005	ALL	Body	Passenger Door Module																																																								
K	2005	ALL	Body	Passenger Presence System																																																								
K	2005	ALL	Body	Base Radio																																																								
K	2005	ALL	Body	Uplevel Radio																																																								
K	2005	ALL	Body	Navigation Radio																																																								
K	2005	ALL	Body	Rear Aux. Climate Module	V																																																								
K	2005	ALL	Body	Rear HVAC																																																								
K	2005	ALL	Body	Rear Seat Audio																																																								
K	2005	ALL	Body	Supplemental Inflatable Restraint		V																																																							
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2005	ALL	Body	Vehicle Theft Deterrent																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																			V	V																					
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																								
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																							V	V	V	V	V														
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																						V						V													
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																								V	V	V															
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																							V	V	V	V	V														
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																						V						V													
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								V	V	V															
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																						V						V													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2006	ALL	Chassis	ESC																																																									
K	2006	ALL	Chassis	Tire Pressure Monitor																																																										
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2006	ALL	Chassis	VSES																																																									
K	2006	ALL	Body	Amplifier (Bose)																																																										
K	2006	ALL	Body	Body Control Module																																																										
K	2006	ALL	Body	CD Changer																																																										
K	2006	ALL	Body	Chime																																																										
K	2006	ALL	Body	Disc Player and Video Display																																																										
K	2006	ALL	Body	Driver Door Module																																																										
K	2006	ALL	Body	Driver Seat Module																																																										
K	2006	ALL	Body	Generator Battery Control Module																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2006	ALL	Body	Instrument Panel Cluster																																																												
K	2006	ALL	Body	Passenger Door Module																																																												
K	2006	ALL	Body	Passenger Presence System																																																												
K	2006	ALL	Body	Base Radio																																																												
K	2006	ALL	Body	Uplevel Radio																																																												
K	2006	ALL	Body	Navigation Radio																																																												
K	2006	ALL	Body	Rear Aux. Climate Module	V																																																											
K	2006	ALL	Body	Rear HVAC																																																												
K	2006	ALL	Body	Rear Seat Audio																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint			V																																																								
K	2006	ALL	Body	Vehicle Theft Deterrent																																																												
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																							
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES					V																																																							
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Avalanche	Chassis	Electronic Suspension Control																																																												
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																																												
K	2007	Avalanche	Body	Amplifier (Bose)																																																												
K	2007	Avalanche	Body	Assist Step Controller																																																												
K	2007	Avalanche	Body	Body Control Module																																																												
K	2007	Avalanche	Body	Body Control Module (aux.)																																																												
K	2007	Avalanche	Body	Digital Radio Receiver																																																												
K	2007	Avalanche	Body	Driver Door Switch																																																												
K	2007	Avalanche	Body	HVAC Control Module Auto						V																																																						
K	2007	Avalanche	Body	HVAC Control Module Manual						V																																																						
K	2007	Avalanche	Body	Instrument Panel Cluster																																																												
K	2007	Avalanche	Body	Memory Seat Module							V																																																					
K	2007	Avalanche	Body	Park Assist Module								V																																																				
K	2007	Avalanche	Body	Passenger Door Switch																																																												
K	2007	Avalanche	Body	Passenger Presence System																																																												
K	2007	Avalanche	Body	Radio																																																											
K	2007	Avalanche	Body	Rear Heated Seat Module																																																												
K	2007	Avalanche	Body	Rear HVAC/RSA																																																												
K	2007	Avalanche	Body	Rollover Sensor																																																												
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																												
K	2007	Avalanche	Body	Theft Deterrent Module																																																												
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																														V												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																														V												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																														V												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																														V												
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																						
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2007	Suburban	Chassis	Electronic Suspension Control																																																											
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																											
K	2007	Suburban	Body	Amplifier (Bose)																																																											
K	2007	Suburban	Body	Assist Step Controller																																																											
K	2007	Suburban	Body	Body Control Module																																																											
K	2007	Suburban	Body	Body Control Module (aux.)																																																											
K	2007	Suburban	Body	Digital Radio Receiver																																																											
K	2007	Suburban	Body	Driver Door Switch																																																											
K	2007	Suburban	Body	HVAC Control Module Auto						V																																									V												
K	2007	Suburban	Body	HVAC Control Module Manual						V																																																					
K	2007	Suburban	Body	Instrument Panel Cluster																																																											
K	2007	Suburban	Body	Lift Gate Module																																																											
K	2007	Suburban	Body	Memory Seat Module							V																																																				
K	2007	Suburban	Body	Park Assist Module								V																																																			
K	2007	Suburban	Body	Passenger Door Switch																																																											
K	2007	Suburban	Body	Passenger Presence System																																																											
K	2007	Suburban	Body	Radio																																																										
K	2007	Suburban	Body	Rear Heated Seat Module																																																											
K	2007	Suburban	Body	Rear HVAC/RSA																																																											
K	2007	Suburban	Body	Rollover Sensor																																																											
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																																											
K	2007	Suburban	Body	Theft Deterrent Module																																																											
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																														V												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																											
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																														V												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																														V												
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																												V												
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																												V												
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																												V												
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																												V												
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V									
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V							
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																						V					V												
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																				
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																			
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2007	Silverado	Chassis	Electronic Suspension Control																																																								
K	2007	Silverado	Chassis	Trailer Brake Control Module																																																								
K	2007	Silverado	Body	Amplifier (Bose)																																																								
K	2007	Silverado	Body	Body Control Module																																																								
K	2007	Silverado	Body	Body Control Module (aux.)																																																								
K	2007	Silverado	Body	Digital Radio Receiver																																																								
K	2007	Silverado	Body	Driver Door Switch																																																								
K	2007	Silverado	Body	HVAC Control Module Auto						V																																							V												
K	2007	Silverado	Body	HVAC Control Module Manual						V																																																			
K	2007	Silverado	Body	Instrument Panel Cluster																																																								
K	2007	Silverado	Body	Memory Seat Module							V																																																	
K	2007	Silverado	Body	Park Assist Module								V																																																
K	2007	Silverado	Body	Passenger Door Switch																																																								
K	2007	Silverado	Body	Passenger Presence System																																																								
K	2007	Silverado	Body	Radio																																																								
K	2007	Silverado	Body	Rear Heated Seat Module																																																								
K	2007	Silverado	Body	Rear HVAC/RSA																																																								
K	2007	Silverado	Body	Rollover Sensor																																																								
K	2007	Silverado	Body	Supplemental Inflatable Restraint																																																								
K	2007	Silverado	Body	Theft Deterrent Module																																																								
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																												V												
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																												V												
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																													V													
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																					
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES					V																																																					
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																									
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																									
K	2007	Tahoe	Body	Amplifier (Bose)																																																									
K	2007	Tahoe	Body	Assist Step Controller																																																									
K	2007	Tahoe	Body	Body Control Module																																																									
K	2007	Tahoe	Body	Body Control Module (aux.)																																																									
K	2007	Tahoe	Body	Digital Radio Receiver																																																									
K	2007	Tahoe	Body	Driver Door Switch																																																									
K	2007	Tahoe	Body	HVAC Control Module Auto						V																																										V											
K	2007	Tahoe	Body	HVAC Control Module Manual						V																																																				
K	2007	Tahoe	Body	Instrument Panel Cluster																																																									
K	2007	Tahoe	Body	Lift Gate Module																																																									
K	2007	Tahoe	Body	Memory Seat Module							V																																																		
K	2007	Tahoe	Body	Park Assist Module								V																																																
K	2007	Tahoe	Body	Passenger Door Switch																																																									
K	2007	Tahoe	Body	Passenger Presence System																																																									
K	2007	Tahoe	Body	Radio																																																									
K	2007	Tahoe	Body	Rear Heated Seat Module																																																									
K	2007	Tahoe	Body	Rear HVAC/RSA																																																									
K	2007	Tahoe	Body	Rollover Sensor																																																									
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																									
K	2007	Tahoe	Body	Theft Deterrent Module																																																									
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																													V													
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																													V													
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																													V													
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																													V													
K	2008	Avalanche	Chassis	Electronic Brake Control Module					V																																																					
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																									
K	2008	Avalanche	Body	Amplifier (Bose)																																																									
K	2008	Avalanche	Body	Assist Step Controller																																																									
K	2008	Avalanche	Body	Body Control Module																																																									
K	2008	Avalanche	Body	Body Control Module (aux.)																																																									
K	2008	Avalanche	Body	Digital Radio Receiver																																																									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2008	Avalanche	Body	Driver Door Switch																																																												
K	2008	Avalanche	Body	HVAC Control Module Auto						V																																									V											
K	2008	Avalanche	Body	HVAC Control Module Manual						V																																																					
K	2008	Avalanche	Body	Instrument Panel Cluster																																																											
K	2008	Avalanche	Body	Memory Seat Module							V																																																				
K	2008	Avalanche	Body	Park Assist Module								V																																																			
K	2008	Avalanche	Body	Passenger Door Switch																																																											
K	2008	Avalanche	Body	Passenger Presence System																																																											
K	2008	Avalanche	Body	Radio																																																										
K	2008	Avalanche	Body	Rear Heated Seat Module																																																											
K	2008	Avalanche	Body	Rear HVAC/RSA																																																											
K	2008	Avalanche	Body	Rollover Sensor																																																											
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2008	Avalanche	Body	Theft Deterrent Module																																																											
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																V											
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																V											
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																V											
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																V											
K	2008	Suburban	Chassis	EBCM Under 8600 GVW																																																											
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW				V																																																							
K	2008	Suburban	Chassis	Electronic Suspension Control																																																											
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																											
K	2008	Suburban	Body	Amplifier (Bose)																																																											
K	2008	Suburban	Body	Assist Step Controller																																																											
K	2008	Suburban	Body	Body Control Module																																																										
K	2008	Suburban	Body	Body Control Module (aux.)																																																											
K	2008	Suburban	Body	Digital Radio Receiver																																																											
K	2008	Suburban	Body	Driver Door Switch																																																											
K	2008	Suburban	Body	HVAC Control Module Auto						V																																											V											
K	2008	Suburban	Body	HVAC Control Module Manual						V																																																					
K	2008	Suburban	Body	Instrument Panel Cluster																																																											
K	2008	Suburban	Body	Lift Gate Module																																																											
K	2008	Suburban	Body	Memory Seat Module							V																																																				
K	2008	Suburban	Body	Park Assist Module								V																																																			
K	2008	Suburban	Body	Passenger Door Switch																																																											
K	2008	Suburban	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2008	Suburban	Body	Radio																																																										
K	2008	Suburban	Body	Rear Heated Seat Module																																																										
K	2008	Suburban	Body	Rear HVAC/RSA																																																										
K	2008	Suburban	Body	Rollover Sensor																																																										
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2008	Suburban	Body	Theft Deterrent Module																																																										
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES					V																																																					
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																					
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Silverado	Chassis	Electronic Suspension Control																																																										
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																										
K	2008	Silverado	Body	Amplifier (Bose)																																																										
K	2008	Silverado	Body	Body Control Module																																																										
K	2008	Silverado	Body	Body Control Module (aux.)																																																										
K	2008	Silverado	Body	Digital Radio Receiver																																																										
K	2008	Silverado	Body	Driver Door Switch																																																										
K	2008	Silverado	Body	HVAC Control Module Auto						V																																										V										
K	2008	Silverado	Body	HVAC Control Module Manual						V																																																				

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2008	Silverado	Body	Instrument Panel Cluster																																																											
K	2008	Silverado	Body	Memory Seat Module							V																																																			
K	2008	Silverado	Body	Park Assist Module								V																																																		
K	2008	Silverado	Body	Passenger Door Switch																																																										
K	2008	Silverado	Body	Passenger Presence System																																																										
K	2008	Silverado	Body	Radio																																																										
K	2008	Silverado	Body	Rear Heated Seat Module																																																										
K	2008	Silverado	Body	Rear HVAC/RSA																																																										
K	2008	Silverado	Body	Rollover Sensor																																																										
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2008	Silverado	Body	Theft Deterrent Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Tahoe	Chassis	Electronic Brake Control Module					V																																																					
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																										
K	2008	Tahoe	Body	Amplifier (Bose)																																																										
K	2008	Tahoe	Body	Assist Step Controller																																																										
K	2008	Tahoe	Body	Body Control Module																																																										
K	2008	Tahoe	Body	Body Control Module (aux.)																																																										
K	2008	Tahoe	Body	Digital Radio Receiver																																																										
K	2008	Tahoe	Body	Driver Door Switch																																																										
K	2008	Tahoe	Body	HVAC Control Module Auto						V																																											V										
K	2008	Tahoe	Body	HVAC Control Module Manual						V																																																				
K	2008	Tahoe	Body	Instrument Panel Cluster																																																										
K	2008	Tahoe	Body	Lift Gate Module																																																										
K	2008	Tahoe	Body	Memory Seat Module							V																																																			
K	2008	Tahoe	Body	Park Assist Module								V																																																		
K	2008	Tahoe	Body	Passenger Door Switch																																																										
K	2008	Tahoe	Body	Passenger Presence System																																																										
K	2008	Tahoe	Body	Radio																																																									
K	2008	Tahoe	Body	Rear Heated Seat Module																																																										
K	2008	Tahoe	Body	Rear HVAC/RSA																																																										
K	2008	Tahoe	Body	Rollover Sensor																																																										
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2008	Tahoe	Body	Theft Deterrent Module																																																										
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																	V	V		V	V				
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																					V	V			
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																				V	V

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																																											
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																											
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																											
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
K	2008	Tahoe Hybrid	Body	Body Control Module																																																											
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																																											
K	2008	Tahoe Hybrid	Body	HVAC Control Module						V																																											V				V						
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																											
K	2008	Tahoe Hybrid	Body	Memory Seat Module							V																																																				
K	2008	Tahoe Hybrid	Body	Park Assist Module								V																																																			
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																																											
K	2008	Tahoe Hybrid	Body	Radio																																																											
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																											
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																											
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																											
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																											
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																											
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																											
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																											
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2009	Avalanche	Chassis	Electronic Brake Control Module					V																																																						
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																											
K	2009	Avalanche	Body	Amplifier (Bose)																																																											
K	2009	Avalanche	Body	Assist Step Controller																																																											
K	2009	Avalanche	Body	Body Control Module																																																											
K	2009	Avalanche	Body	Body Control Module (aux.)																																																											
K	2009	Avalanche	Body	Digital Radio Receiver																																																											
K	2009	Avalanche	Body	Driver Door Switch																																																											
K	2009	Avalanche	Body	HVAC Control Module Auto						V																																											V										
K	2009	Avalanche	Body	HVAC Control Module Manual						V																																																					
K	2009	Avalanche	Body	Instrument Panel Cluster																																																											
K	2009	Avalanche	Body	Memory Seat Module							V																																																				
K	2009	Avalanche	Body	Park Assist Module								V																																																			
K	2009	Avalanche	Body	Passenger Door Switch																																																											
K	2009	Avalanche	Body	Passenger Presence System																																																											
K	2009	Avalanche	Body	Radio																																																											
K	2009	Avalanche	Body	Rear Heated Seat Module																																																											
K	2009	Avalanche	Body	Rear HVAC/RSA																																																											
K	2009	Avalanche	Body	Rollover Sensor																																																											
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2009	Avalanche	Body	Theft Deterrent Module																																																											
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																	V										
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																	V										
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																											
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES					V																																																						
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																							
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																											
K	2009	Cheyenne	Body	Amplifier (Bose)																																																											
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2009	Cheyenne	Body	Digital Radio Receiver																																																											
K	2009	Cheyenne	Body	Driver Door Switch																																																											
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2009	Cheyenne	Body	Park Assist Module								V																																																			
K	2009	Cheyenne	Body	Passenger Door Switch																																																											
K	2009	Cheyenne	Body	Passenger Presence System																																																											
K	2009	Cheyenne	Body	Rear Heated Seat Module																																																											
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2009	Cheyenne	Body	Rollover Sensor																																																											
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
K	2009	Cheyenne	Body	Theft Deterrent Module																																																											
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Suburban	Chassis	EBCM Under 8600 GVW					V																																																							
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2009	Suburban	Chassis	Electronic Suspension Control																																																												
K	2009	Suburban	Chassis	Trailer Brake Control Module				V																																																								
K	2009	Suburban	Body	Amplifier (Bose)																																																												
K	2009	Suburban	Body	Assist Step Controller																																																												
K	2009	Suburban	Body	Body Control Module																																																												
K	2009	Suburban	Body	Body Control Module (aux.)																																																												
K	2009	Suburban	Body	Digital Radio Receiver																																																												
K	2009	Suburban	Body	Driver Door Switch																																																												
K	2009	Suburban	Body	HVAC Control Module Auto						V																																											V											
K	2009	Suburban	Body	HVAC Control Module Manual						V																																																						
K	2009	Suburban	Body	Instrument Panel Cluster																																																												
K	2009	Suburban	Body	Left Side Object Detection Module																																																												
K	2009	Suburban	Body	Lift Gate Module																																																												
K	2009	Suburban	Body	Memory Seat Module							V																																																					
K	2009	Suburban	Body	Park Assist Module								V																																																				
K	2009	Suburban	Body	Passenger Door Switch																																																												
K	2009	Suburban	Body	Passenger Presence System																																																												
K	2009	Suburban	Body	Radio																																																											
K	2009	Suburban	Body	Rear Heated Seat Module																																																												
K	2009	Suburban	Body	Rear HVAC/RSA																																																												
K	2009	Suburban	Body	Right Side Object Detection Module																																																												
K	2009	Suburban	Body	Rollover Sensor																																																												
K	2009	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2009	Suburban	Body	Theft Deterrent Module																																																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																		V											
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																		V											
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																													V													
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																											
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																													V													
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																											
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																											
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																											
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																									V	V	V	V				V	V										
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																									V	V	V							V								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																							V						V													
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES					V																																																						
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES				V																																																							
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2009	Silverado	Chassis	Electronic Suspension Control																																																											
K	2009	Silverado	Chassis	Trailer Brake Control Module				V																																																							
K	2009	Silverado	Body	Amplifier (Bose)																																																											
K	2009	Silverado	Body	Body Control Module																																																										
K	2009	Silverado	Body	Body Control Module (aux.)																																																											
K	2009	Silverado	Body	Digital Radio Receiver																																																											
K	2009	Silverado	Body	Driver Door Switch																																																											
K	2009	Silverado	Body	HVAC Control Module Auto						V																																											V										
K	2009	Silverado	Body	HVAC Control Module Manual						V																																																					
K	2009	Silverado	Body	Instrument Panel Cluster																																																											
K	2009	Silverado	Body	Memory Seat Module							V																																																				
K	2009	Silverado	Body	Park Assist Module								V																																																			
K	2009	Silverado	Body	Passenger Door Switch																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2009	Silverado	Body	Passenger Presence System																																																												
K	2009	Silverado	Body	Radio																																																												
K	2009	Silverado	Body	Rear Heated Seat Module																																																												
K	2009	Silverado	Body	Rear HVAC/RSA																																																												
K	2009	Silverado	Body	Rollover Sensor																																																												
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2009	Silverado	Body	Theft Deterrent Module																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																	V	V		V	V					
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																						V	V			
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																						V	V
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2009	Silverado Hybrid	Body	Body Control Module																																																												
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2009	Silverado Hybrid	Body	HVAC Control Module						V																																										V			V						
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2009	Silverado Hybrid	Body	Memory Seat Module							V																																																					
K	2009	Silverado Hybrid	Body	Park Assist Module								V																																																				
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2009	Silverado Hybrid	Body	Passenger Presence System																																																												
K	2009	Silverado Hybrid	Body	Radio																																																												
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																												
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																												
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																												V														
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Tahoe	Chassis	Electronic Brake Control Module					V																																																							
K	2009	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																																												
K	2009	Tahoe	Body	Amplifier (Bose)																																																												
K	2009	Tahoe	Body	Assist Step Controller																																																												
K	2009	Tahoe	Body	Body Control Module																																																												
K	2009	Tahoe	Body	Body Control Module (aux.)																																																												
K	2009	Tahoe	Body	Digital Radio Receiver																																																												
K	2009	Tahoe	Body	Driver Door Switch																																																												
K	2009	Tahoe	Body	HVAC Control Module Auto						V																																										V											
K	2009	Tahoe	Body	HVAC Control Module Manual						V																																																					
K	2009	Tahoe	Body	Instrument Panel Cluster																																																												
K	2009	Tahoe	Body	Left Side Object Detection Module																																																												
K	2009	Tahoe	Body	Lift Gate Module																																																												
K	2009	Tahoe	Body	Memory Seat Module							V																																																				
K	2009	Tahoe	Body	Park Assist Module								V																																																			
K	2009	Tahoe	Body	Passenger Door Switch																																																												
K	2009	Tahoe	Body	Passenger Presence System																																																												
K	2009	Tahoe	Body	Radio																																																											
K	2009	Tahoe	Body	Rear Heated Seat Module																																																												
K	2009	Tahoe	Body	Rear HVAC/RSA																																																												
K	2009	Tahoe	Body	Right Side Object Detection Module																																																												
K	2009	Tahoe	Body	Rollover Sensor																																																												
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2009	Tahoe	Body	Theft Deterrent Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																V	V		V	V				
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																				V	V				
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																					V	V
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																																												
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																												
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
K	2009	Tahoe Hybrid	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																																												
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																																												
K	2009	Tahoe Hybrid	Body	HVAC Control Module						V																																										V			V							
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
K	2009	Tahoe Hybrid	Body	Park Assist Module								V																																																			
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																												
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																																												
K	2009	Tahoe Hybrid	Body	Radio																																																												
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																												
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																	
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																																
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Avalanche	Chassis	Electronic Brake Control Module					V																																																							
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																												
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Avalanche	Body	Amplifier (Bose)																																																												
K	2010	Avalanche	Body	Assist Step Controller																																																												
K	2010	Avalanche	Body	Body Control Module																																																												
K	2010	Avalanche	Body	Body Control Module (aux.)																																																												
K	2010	Avalanche	Body	Digital Radio Receiver																																																												
K	2010	Avalanche	Body	Driver Door Switch																																																												
K	2010	Avalanche	Body	HVAC Control Module Auto						V																																										V										
K	2010	Avalanche	Body	HVAC Control Module Manual						V																																																					
K	2010	Avalanche	Body	Instrument Panel Cluster																																																												
K	2010	Avalanche	Body	Memory Seat Module							V																																																				
K	2010	Avalanche	Body	Park Assist Module																																																												
K	2010	Avalanche	Body	Passenger Door Switch																																																												
K	2010	Avalanche	Body	Passenger Presence System																																																												
K	2010	Avalanche	Body	Radio																																																											
K	2010	Avalanche	Body	Rear Heated Seat Module																																																												
K	2010	Avalanche	Body	Rear HVAC/RSA																																																												
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																												
K	2010	Avalanche	Body	Theft Deterrent Module																																																												
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																																	
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES					V																																																					
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																						
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Cheyenne	Body	Amplifier (Bose)																																																										
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2010	Cheyenne	Body	Digital Radio Receiver																																																										
K	2010	Cheyenne	Body	Driver Door Switch																																																										
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2010	Cheyenne	Body	Park Assist Module																																																										
K	2010	Cheyenne	Body	Passenger Door Switch																																																										
K	2010	Cheyenne	Body	Passenger Presence System																																																										
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2010	Cheyenne	Body	Theft Deterrent Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																															
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Suburban	Chassis	EBCM Under 8600 GVW					V																																																					
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW				V																																																						
K	2010	Suburban	Chassis	Electronic Suspension Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Suburban	Body	Amplifier (Bose)																																																										
K	2010	Suburban	Body	Assist Step Controller																																																										
K	2010	Suburban	Body	Body Control Module																																																										
K	2010	Suburban	Body	Body Control Module (aux.)																																																										
K	2010	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2010	Suburban	Body	Driver Door Switch																																																											
K	2010	Suburban	Body	HVAC Control Module Auto						V																																									V											
K	2010	Suburban	Body	HVAC Control Module Manual						V																																																				
K	2010	Suburban	Body	Instrument Panel Cluster																																																										
K	2010	Suburban	Body	Left Side Object Detection Module																																																										
K	2010	Suburban	Body	Lift Gate Module																																																										
K	2010	Suburban	Body	Memory Seat Module							V																																																			
K	2010	Suburban	Body	Park Assist Module																																																										
K	2010	Suburban	Body	Passenger Door Switch																																																										
K	2010	Suburban	Body	Passenger Presence System																																																										
K	2010	Suburban	Body	Radio																																																										
K	2010	Suburban	Body	Rear Heated Seat Module																																																										
K	2010	Suburban	Body	Rear HVAC/RSA																																																										
K	2010	Suburban	Body	Right Side Object Detection Module																																																										
K	2010	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2010	Suburban	Body	Theft Deterrent Module																																																										
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																V											
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module											V	V																																														
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																V											
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																															
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																										
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																														
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V									
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																							V					V														
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES					V																																																					
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																					
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES				V																																																						

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2010	Silverado	Chassis	Electronic Suspension Control																																																												
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control				V																																																								
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2010	Silverado	Body	Amplifier (Bose)																																																												
K	2010	Silverado	Body	Body Control Module																																																												
K	2010	Silverado	Body	Body Control Module (aux.)																																																												
K	2010	Silverado	Body	Digital Radio Receiver																																																												
K	2010	Silverado	Body	Driver Door Switch																																																												
K	2010	Silverado	Body	HVAC Control Module Auto						V																																									V												
K	2010	Silverado	Body	HVAC Control Module Manual						V																																																						
K	2010	Silverado	Body	Instrument Panel Cluster																																																												
K	2010	Silverado	Body	Memory Seat Module							V																																																					
K	2010	Silverado	Body	Park Assist Module																																																												
K	2010	Silverado	Body	Passenger Door Switch																																																												
K	2010	Silverado	Body	Passenger Presence System																																																												
K	2010	Silverado	Body	Radio																																																												
K	2010	Silverado	Body	Rear Heated Seat Module																																																												
K	2010	Silverado	Body	Rear HVAC/RSA																																																												
K	2010	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2010	Silverado	Body	Theft Deterrent Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																V	V		V	V						
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																						V	V			
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																						V	V
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																																												
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Silverado Hybrid	Body	Body Control Module																																																												
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2010	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2010	Silverado Hybrid	Body	Heated Seat Module																																																												
K	2010	Silverado Hybrid	Body	HVAC Control Module						V																																												V									
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2010	Silverado Hybrid	Body	Park Assist Module																																																												
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2010	Silverado Hybrid	Body	Passenger Presence System																																																												
K	2010	Silverado Hybrid	Body	Radio																																																												
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																															
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Tahoe	Chassis	Electronic Brake Control Module					V																																																					
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Tahoe	Body	Amplifier (Bose)																																																										
K	2010	Tahoe	Body	Assist Step Controller																																																										
K	2010	Tahoe	Body	Body Control Module																																																										
K	2010	Tahoe	Body	Body Control Module (aux.)																																																										
K	2010	Tahoe	Body	Digital Radio Receiver																																																										
K	2010	Tahoe	Body	Driver Door Switch																																																										
K	2010	Tahoe	Body	HVAC Control Module Auto						V																																								V												
K	2010	Tahoe	Body	HVAC Control Module Manual						V																																																				
K	2010	Tahoe	Body	Instrument Panel Cluster																																																										
K	2010	Tahoe	Body	Left Side Object Detection Module																																																										
K	2010	Tahoe	Body	Lift Gate Module																																																										
K	2010	Tahoe	Body	Memory Seat Module							V																																																			
K	2010	Tahoe	Body	Park Assist Module																																																										
K	2010	Tahoe	Body	Passenger Door Switch																																																										
K	2010	Tahoe	Body	Passenger Presence System																																																										
K	2010	Tahoe	Body	Radio																																																										
K	2010	Tahoe	Body	Rear Heated Seat Module																																																										
K	2010	Tahoe	Body	Rear HVAC/RSA																																																										
K	2010	Tahoe	Body	Right Side Object Detection Module																																																										
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2010	Tahoe	Body	Theft Deterrent Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																															V	V		V	V							
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																				V	V					
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																						V	V
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Tahoe Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																																											
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																																											
K	2010	Tahoe Hybrid	Body	HVAC Control Module						V																																													V							
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																											
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																																											
K	2010	Tahoe Hybrid	Body	Park Assist Module																																																											
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																											
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																																											
K	2010	Tahoe Hybrid	Body	Radio																																																											
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																											
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																											
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																											
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																											
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																											
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																																
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module									V	V	V																																																
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module									V	V	V																																																
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2011	Avalanche	Chassis	Electronic Brake Control Module					V																																																						
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Avalanche	Body	Amplifier (Bose)																																																											
K	2011	Avalanche	Body	Assist Step Controller																																																											
K	2011	Avalanche	Body	Body Control Module																																																											
K	2011	Avalanche	Body	Body Control Module (aux.)																																																											
K	2011	Avalanche	Body	Digital Radio Receiver																																																											
K	2011	Avalanche	Body	Driver Door Switch																																																											
K	2011	Avalanche	Body	HVAC Control Module Auto						V																																												V							
K	2011	Avalanche	Body	HVAC Control Module Manual						V																																																					
K	2011	Avalanche	Body	Instrument Panel Cluster																																																											
K	2011	Avalanche	Body	Memory Seat Module							V																																																				
K	2011	Avalanche	Body	Park Assist Module																																																											
K	2011	Avalanche	Body	Passenger Door Switch																																																											
K	2011	Avalanche	Body	Passenger Presence System																																																											
K	2011	Avalanche	Body	Radio																																																										
K	2011	Avalanche	Body	Rear Heated Seat Module																																																											
K	2011	Avalanche	Body	Rear HVAC/RSA																																																											
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2011	Avalanche	Body	Theft Deterrent Module																																																											
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																																
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES					V																																																						
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																											
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																							
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																											
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Cheyenne	Body	Amplifier (Bose)																																																											
K	2011	Cheyenne	Body	Body Control Module																																																											
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2011	Cheyenne	Body	Digital Radio Receiver																																																											
K	2011	Cheyenne	Body	Driver Door Switch																																																											
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2011	Cheyenne	Body	Park Assist Module																																																											
K	2011	Cheyenne	Body	Passenger Door Switch																																																											
K	2011	Cheyenne	Body	Passenger Presence System																																																											
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																											
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
K	2011	Cheyenne	Body	Theft Deterrent Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2011	Suburban	Chassis	EBCM Under 8600 GVW					V																																																						
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW				V																																																							
K	2011	Suburban	Chassis	Electronic Suspension Control																																																											
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Suburban	Body	Amplifier (Bose)																																																											
K	2011	Suburban	Body	Assist Step Controller																																																											
K	2011	Suburban	Body	Body Control Module																																																										
K	2011	Suburban	Body	Body Control Module (aux.)																																																											
K	2011	Suburban	Body	Digital Radio Receiver																																																											
K	2011	Suburban	Body	Driver Door Switch																																																											
K	2011	Suburban	Body	HVAC Control Module Auto						V																																																					
K	2011	Suburban	Body	HVAC Control Module Manual						V																																																					

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2011	Suburban	Body	Instrument Panel Cluster																																																														
K	2011	Suburban	Body	Left Side Object Detection Module																																																													
K	2011	Suburban	Body	Lift Gate Module																																																													
K	2011	Suburban	Body	Memory Seat Module							V																																																					
K	2011	Suburban	Body	Park Assist Module																																																												
K	2011	Suburban	Body	Passenger Door Switch																																																												
K	2011	Suburban	Body	Passenger Presence System																																																												
K	2011	Suburban	Body	Radio																																																											
K	2011	Suburban	Body	Rear Heated Seat Module																																																												
K	2011	Suburban	Body	Rear HVAC/RSA																																																												
K	2011	Suburban	Body	Right Side Object Detection Module																																																												
K	2011	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2011	Suburban	Body	Theft Deterrent Module																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module											V	V																																															
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module									V	V	V																																																		
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																																	
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																																
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V	V	V	V				V	V											
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								V	V	V																
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																						V						V													
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V										
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V																
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																											
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																											
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																						V						V													
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES					V																																																						
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES				V																																																							

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2011	Silverado	Chassis	Electronic Suspension Control																																																												
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																											
K	2011	Silverado	Body	Amplifier (Bose)																																																											
K	2011	Silverado	Body	Body Control Module																																																										
K	2011	Silverado	Body	Body Control Module (aux.)																																																										
K	2011	Silverado	Body	Digital Radio Receiver																																																										
K	2011	Silverado	Body	Driver Door Switch																																																										
K	2011	Silverado	Body	HVAC Control Module Auto						V																																									V											
K	2011	Silverado	Body	HVAC Control Module Manual						V																																																				
K	2011	Silverado	Body	Instrument Panel Cluster																																																										
K	2011	Silverado	Body	Memory Seat Module							V																																																		
K	2011	Silverado	Body	Park Assist Module																																																										
K	2011	Silverado	Body	Passenger Door Switch																																																										
K	2011	Silverado	Body	Passenger Presence System																																																										
K	2011	Silverado	Body	Radio																																																										
K	2011	Silverado	Body	Rear Heated Seat Module																																																										
K	2011	Silverado	Body	Rear HVAC/RSA																																																										
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2011	Silverado	Body	Theft Deterrent Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																V	V		V	V					
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																				V	V			
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																				V	V
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2011	Silverado Hybrid	Body	Body Control Module																																																										
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2011	Silverado Hybrid	Body	HVAC Control Module						V																																												V									
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2011	Silverado Hybrid	Body	Park Assist Module																																																										
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2011	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2011	Silverado Hybrid	Body	Radio																																																										
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																											
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2011	Tahoe	Chassis	Electronic Brake Control Module					V																																																					
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Tahoe	Body	Amplifier (Bose)																																																										
K	2011	Tahoe	Body	Assist Step Controller																																																										
K	2011	Tahoe	Body	Body Control Module																																																										
K	2011	Tahoe	Body	Body Control Module (aux.)																																																										
K	2011	Tahoe	Body	Digital Radio Receiver																																																										
K	2011	Tahoe	Body	Driver Door Switch																																																										
K	2011	Tahoe	Body	HVAC Control Module Auto						V																																										V											
K	2011	Tahoe	Body	HVAC Control Module Manual						V																																																					
K	2011	Tahoe	Body	Instrument Panel Cluster																																																										
K	2011	Tahoe	Body	Left Side Object Detection Module																																																										
K	2011	Tahoe	Body	Lift Gate Module																																																										
K	2011	Tahoe	Body	Memory Seat Module							V																																																			
K	2011	Tahoe	Body	Park Assist Module																																																										
K	2011	Tahoe	Body	Passenger Door Switch																																																										
K	2011	Tahoe	Body	Passenger Presence System																																																										
K	2011	Tahoe	Body	Radio																																																										
K	2011	Tahoe	Body	Rear Heated Seat Module																																																										
K	2011	Tahoe	Body	Rear HVAC/RSA																																																										
K	2011	Tahoe	Body	Right Side Object Detection Module																																																										
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2011	Tahoe	Body	Theft Deterrent Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																V	V		V	V					
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																					V	V			
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																					V	V
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
K	2011	Tahoe Hybrid	Body	Body Control Module																																																										
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																																										
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																																										
K	2011	Tahoe Hybrid	Body	HVAC Control Module						V																																													V							

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2011	Tahoe Hybrid	Body	Radio																																																										
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2012	Avalanche	Chassis	Electronic Brake Control Module					V																																																					
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Avalanche	Body	Amplifier (Bose)																																																										
K	2012	Avalanche	Body	Assist Step Controller																																																										
K	2012	Avalanche	Body	Body Control Module																																																										
K	2012	Avalanche	Body	Body Control Module (aux.)																																																										
K	2012	Avalanche	Body	Digital Radio Receiver																																																										
K	2012	Avalanche	Body	Driver Door Switch																																																										
K	2012	Avalanche	Body	HVAC Control Module Auto						V																																										V										
K	2012	Avalanche	Body	HVAC Control Module Manual						V																																																				
K	2012	Avalanche	Body	Instrument Panel Cluster																																																										
K	2012	Avalanche	Body	Memory Seat Module							V																																																			
K	2012	Avalanche	Body	Navigation Radio																																																										
K	2012	Avalanche	Body	Park Assist Module																																																										
K	2012	Avalanche	Body	Passenger Door Switch																																																										
K	2012	Avalanche	Body	Passenger Presence System																																																										
K	2012	Avalanche	Body	Radio																																																										
K	2012	Avalanche	Body	Rear Heated Seat Module																																																										
K	2012	Avalanche	Body	Rear HVAC/RSA																																																										
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2012	Avalanche	Body	Theft Deterrent Module																																																										
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																V										
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																																
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES					V																																																						
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																							
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																											
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Cheyenne	Body	Amplifier (Bose)																																																											
K	2012	Cheyenne	Body	Body Control Module																																																											
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2012	Cheyenne	Body	Digital Radio Receiver																																																											
K	2012	Cheyenne	Body	Driver Door Switch																																																											
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2012	Cheyenne	Body	Park Assist Module																																																											
K	2012	Cheyenne	Body	Passenger Door Switch																																																											
K	2012	Cheyenne	Body	Passenger Presence System																																																											
K	2012	Cheyenne	Body	Rear Heated Seat Module																																																											
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
K	2012	Cheyenne	Body	Theft Deterrent Module																																																											
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																																
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2012	Suburban	Chassis	EBCM Under 8600 GVW					V																																																						
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW				V																																																							
K	2012	Suburban	Chassis	Electronic Suspension Control																																																											
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2012	Suburban	Body	Amplifier (Bose)																																																											
K	2012	Suburban	Body	Assist Step Controller																																																											
K	2012	Suburban	Body	Body Control Module																																																											
K	2012	Suburban	Body	Body Control Module (aux.)																																																											
K	2012	Suburban	Body	Digital Radio Receiver																																																											
K	2012	Suburban	Body	Driver Door Switch																																																											
K	2012	Suburban	Body	HVAC Control Module Auto						V																																																					
K	2012	Suburban	Body	HVAC Control Module Manual						V																																																					
K	2012	Suburban	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2012	Suburban	Body	Left Side Object Detection Module																																																											
K	2012	Suburban	Body	Lift Gate Module																																																											
K	2012	Suburban	Body	Memory Seat Module							V																																																			
K	2012	Suburban	Body	Navigation Radio																																																										
K	2012	Suburban	Body	Park Assist Module																																																										
K	2012	Suburban	Body	Passenger Door Switch																																																										
K	2012	Suburban	Body	Passenger Presence System																																																										
K	2012	Suburban	Body	Radio																																																										
K	2012	Suburban	Body	Rear Heated Seat Module																																																										
K	2012	Suburban	Body	Rear HVAC/RSA																																																										
K	2012	Suburban	Body	Right Side Object Detection Module																																																										
K	2012	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2012	Suburban	Body	Theft Deterrent Module																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																													V														
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																													V														
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual									V		V																																															
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module									V	V	V																																															
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V	V	V	V				V	V										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								V	V	V															
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																							V					V														
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V															
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																										
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																													V														
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES					V																																																					
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																					
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES				V																																																					
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2012	Silverado	Chassis	Electronic Suspension Control																																																										
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2012	Silverado	Body	Amplifier (Bose)																																																										
K	2012	Silverado	Body	Body Control Module																																																										
K	2012	Silverado	Body	Body Control Module (aux.)																																																										
K	2012	Silverado	Body	Digital Radio Receiver																																																										
K	2012	Silverado	Body	Driver Door Switch																																																										
K	2012	Silverado	Body	HVAC Control Module Auto						V																																								V												
K	2012	Silverado	Body	HVAC Control Module Manual						V																																																				
K	2012	Silverado	Body	Instrument Panel Cluster																																																										
K	2012	Silverado	Body	Memory Seat Module							V																																																			
K	2012	Silverado	Body	Navigation Radio																																																										
K	2012	Silverado	Body	Park Assist Module																																																										
K	2012	Silverado	Body	Passenger Door Switch																																																										
K	2012	Silverado	Body	Passenger Presence System																																																										
K	2012	Silverado	Body	Radio																																																										
K	2012	Silverado	Body	Rear Heated Seat Module																																																										
K	2012	Silverado	Body	Rear HVAC/RSA																																																										
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2012	Silverado	Body	Theft Deterrent Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																														V	V		V	V								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																				V	V					
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																		V																					V	V		
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2012	Silverado Hybrid	Body	Body Control Module																																																										
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2012	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2012	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2012	Silverado Hybrid	Body	HVAC Control Module						V																																												V								
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2012	Silverado Hybrid	Body	Navigation Radio																																																										
K	2012	Silverado Hybrid	Body	Park Assist Module																																																										
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2012	Silverado Hybrid	Body	Passenger Presence System																																																										
K	2012	Silverado Hybrid	Body	Radio																																																										
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																														
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																			
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																															
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																															
K	2012	Tahoe	Chassis	EBCM with Trailer Brake					V																																																										
K	2012	Tahoe	Chassis	Electronic Suspension Control																																																															
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																															
K	2012	Tahoe	Body	Amplifier (Bose)																																																															
K	2012	Tahoe	Body	Assist Step Controller																																																															
K	2012	Tahoe	Body	Body Control Module																																																															
K	2012	Tahoe	Body	Body Control Module (aux.)																																																															
K	2012	Tahoe	Body	Digital Radio Receiver																																																															
K	2012	Tahoe	Body	Driver Door Switch																																																															
K	2012	Tahoe	Body	HVAC Control Module Auto						V																																										V														
K	2012	Tahoe	Body	HVAC Control Module Manual						V																																																									
K	2012	Tahoe	Body	Instrument Panel Cluster																																																															
K	2012	Tahoe	Body	Left Side Object Detection Module																																																															
K	2012	Tahoe	Body	Lift Gate Module																																																															
K	2012	Tahoe	Body	Memory Seat Module							V																																																							
K	2012	Tahoe	Body	Navigation Radio																																																															
K	2012	Tahoe	Body	Park Assist Module																																																															
K	2012	Tahoe	Body	Passenger Door Switch																																																															
K	2012	Tahoe	Body	Passenger Presence System																																																															
K	2012	Tahoe	Body	Radio																																																															
K	2012	Tahoe	Body	Rear Heated Seat Module																																																															
K	2012	Tahoe	Body	Rear HVAC/RSA																																																															
K	2012	Tahoe	Body	Right Side Object Detection Module																																																															
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																															
K	2012	Tahoe	Body	Theft Deterrent Module																																																															
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																	V	V		V	V							
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																															
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										V	V				
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																															
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																									V	V
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																														
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																														
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																															
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																															
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																															
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																																															
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																															
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																															
K	2012	Tahoe Hybrid	Body	Body Control Module																																																															
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																															
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																															
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																																															
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																																															

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2012	Tahoe Hybrid	Body	HVAC Control Module						V																																														V							
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																																										
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																										
K	2012	Tahoe Hybrid	Body	Park Assist Module																																																										
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																										
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																																										
K	2012	Tahoe Hybrid	Body	Radio																																																										
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																										
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Avalanche	Chassis	Electronic Brake Control Module					V																																																					
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																										
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Avalanche	Body	Amplifier (Bose)																																																										
K	2013	Avalanche	Body	Assist Step Controller																																																										
K	2013	Avalanche	Body	Body Control Module																																																										
K	2013	Avalanche	Body	Body Control Module (aux.)																																																										
K	2013	Avalanche	Body	Digital Radio Receiver																																																										
K	2013	Avalanche	Body	Driver Door Switch																																																										
K	2013	Avalanche	Body	HVAC Control Module Auto						V																																											V										
K	2013	Avalanche	Body	HVAC Control Module Manual						V																																																				
K	2013	Avalanche	Body	Instrument Panel Cluster																																																										
K	2013	Avalanche	Body	Memory Seat Module							V																																																		
K	2013	Avalanche	Body	Navigation Radio																																																										
K	2013	Avalanche	Body	Park Assist Module																																																										
K	2013	Avalanche	Body	Passenger Door Switch																																																										
K	2013	Avalanche	Body	Passenger Presence System																																																										
K	2013	Avalanche	Body	Radio																																																										
K	2013	Avalanche	Body	Rear Heated Seat Module																																																										
K	2013	Avalanche	Body	Rear HVAC/RSA																																																										
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																										
K	2013	Avalanche	Body	Theft Deterrent Module																																																										
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																	V										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES					V																																																					
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES					V																																																					
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																						
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																										
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																										
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Cheyenne	Body	Amplifier (Bose)																																																										
K	2013	Cheyenne	Body	Body Control Module																																																										
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																										
K	2013	Cheyenne	Body	Digital Radio Receiver																																																										
K	2013	Cheyenne	Body	Driver Door Switch																																																										
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																										
K	2013	Cheyenne	Body	Park Assist Module																																																										
K	2013	Cheyenne	Body	Passenger Door Switch																																																										
K	2013	Cheyenne	Body	Passenger Presence System																																																										
K	2013	Cheyenne	Body	Rear Heated Seat Module																																																										
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																										
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																										
K	2013	Cheyenne	Body	Theft Deterrent Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed									V	V	V																																															
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2013	Suburban	Chassis	EBCM Under 8600 GVW					V																																																					
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW				V																																																						
K	2013	Suburban	Chassis	Electronic Suspension Control																																																										
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Suburban	Body	Amplifier (Bose)																																																										
K	2013	Suburban	Body	Assist Step Controller																																																										
K	2013	Suburban	Body	Body Control Module																																																										
K	2013	Suburban	Body	Body Control Module (aux.)																																																										
K	2013	Suburban	Body	Digital Radio Receiver																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2013	Suburban	Body	Driver Door Switch																																																											
K	2013	Suburban	Body	HVAC Control Module Auto						V																																									V											
K	2013	Suburban	Body	HVAC Control Module Manual						V																																																				
K	2013	Suburban	Body	Instrument Panel Cluster																																																										
K	2013	Suburban	Body	Left Side Object Detection Module																																																										
K	2013	Suburban	Body	Lift Gate Module																																																										
K	2013	Suburban	Body	Memory Seat Module							V																																																			
K	2013	Suburban	Body	Navigation Radio																																																										
K	2013	Suburban	Body	Park Assist Module																																																										
K	2013	Suburban	Body	Passenger Door Switch																																																										
K	2013	Suburban	Body	Passenger Presence System																																																										
K	2013	Suburban	Body	Radio																																																										
K	2013	Suburban	Body	Rear Heated Seat Module																																																										
K	2013	Suburban	Body	Rear HVAC/RSA																																																										
K	2013	Suburban	Body	Right Side Object Detection Module																																																										
K	2013	Suburban	Body	Supplemental Inflatable Restraint																																																										
K	2013	Suburban	Body	Theft Deterrent Module																																																										
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																										
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																										
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																V											
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																														
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																V											
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																														
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																														
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																										
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual									V		V																																														
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module									V	V	V																																														
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V	V	V	V				V	V									
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								V	V	V															
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																							V						V											
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES					V																																																					

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES					V																																																					
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES				V																																																						
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2013	Silverado	Chassis	Electronic Suspension Control																																																										
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																										
K	2013	Silverado	Body	Amplifier (Bose)																																																										
K	2013	Silverado	Body	Body Control Module																																																										
K	2013	Silverado	Body	Body Control Module (aux.)																																																										
K	2013	Silverado	Body	Digital Radio Receiver																																																										
K	2013	Silverado	Body	Driver Door Switch																																																										
K	2013	Silverado	Body	HVAC Control Module Auto						V																																									V										
K	2013	Silverado	Body	HVAC Control Module Manual						V																																																				
K	2013	Silverado	Body	Instrument Panel Cluster																																																										
K	2013	Silverado	Body	Memory Seat Module							V																																																		
K	2013	Silverado	Body	Navigation Radio																																																										
K	2013	Silverado	Body	Park Assist Module																																																										
K	2013	Silverado	Body	Passenger Door Switch																																																										
K	2013	Silverado	Body	Passenger Presence System																																																										
K	2013	Silverado	Body	Radio																																																										
K	2013	Silverado	Body	Rear Heated Seat Module																																																										
K	2013	Silverado	Body	Rear HVAC/RSA																																																										
K	2013	Silverado	Body	Supplemental Inflatable Restraint																																																										
K	2013	Silverado	Body	Theft Deterrent Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																															V	V		V	V					
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																			V	V				
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																				V	V
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																										
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																																										
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																										
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																										
K	2013	Silverado Hybrid	Body	Body Control Module																																																										
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																										
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																										
K	2013	Silverado Hybrid	Body	Driver Door Switch																																																										
K	2013	Silverado Hybrid	Body	Heated Seat Module																																																										
K	2013	Silverado Hybrid	Body	HVAC Control Module						V																																												V									
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																										
K	2013	Silverado Hybrid	Body	Navigation Radio																																																										
K	2013	Silverado Hybrid	Body	Park Assist Module																																																										
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																																										
K	2013	Silverado Hybrid	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2013	Silverado Hybrid	Body	Radio																																																										
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																										
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																										
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																										
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2013	Tahoe	Chassis	Electronic Brake Control Module					V																																																					
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																										
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe	Body	Amplifier (Bose)																																																										
K	2013	Tahoe	Body	Assist Step Controller																																																										
K	2013	Tahoe	Body	Body Control Module																																																										
K	2013	Tahoe	Body	Body Control Module (aux.)																																																										
K	2013	Tahoe	Body	Digital Radio Receiver																																																										
K	2013	Tahoe	Body	Driver Door Switch																																																										
K	2013	Tahoe	Body	HVAC Control Module Auto						V																																								V												
K	2013	Tahoe	Body	HVAC Control Module Manual						V																																																				
K	2013	Tahoe	Body	Instrument Panel Cluster																																																										
K	2013	Tahoe	Body	Left Side Object Detection Module																																																										
K	2013	Tahoe	Body	Lift Gate Module																																																										
K	2013	Tahoe	Body	Memory Seat Module							V																																																			
K	2013	Tahoe	Body	Navigation Radio																																																										
K	2013	Tahoe	Body	Park Assist Module																																																										
K	2013	Tahoe	Body	Passenger Door Switch																																																										
K	2013	Tahoe	Body	Passenger Presence System																																																										
K	2013	Tahoe	Body	Radio																																																										
K	2013	Tahoe	Body	Rear Heated Seat Module																																																										
K	2013	Tahoe	Body	Rear HVAC/RSA																																																										
K	2013	Tahoe	Body	Right Side Object Detection Module																																																										
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																										
K	2013	Tahoe	Body	Theft Deterrent Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																															V	V		V	V							
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																				V	V				
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																					V	V	
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																																										
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																														
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																														
K	2013	Tahoe Hybrid	Body	Body Control Module																																																														
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																													
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																													
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																													
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																													
K	2013	Tahoe Hybrid	Body	HVAC Control Module						V																																															V						
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																													
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																													
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																																													
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																													
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																													
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																													
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																																													
K	2013	Tahoe Hybrid	Body	Radio																																																													
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																													
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																													
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																													
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																													
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																													
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																													
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																													
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																													
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																													
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																													
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																													
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																		
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																													
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																													
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																															
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																															
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																													
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																													
K	2014	Cheyenne	Chassis	Power Steering Control Module																														V	V																													
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																													
K	2014	Cheyenne	Body	Body Control Module																																																													
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
K	2014	Cheyenne	Body	Passenger Presence Module																																																													
K	2014	Cheyenne	Body	Instrument Cluster																																																													
K	2014	Cheyenne	Body	Radio Control																																																													
K	2014	Cheyenne	Body	HVAC Control																																																													
K	2014	Cheyenne	Body	Radio																																																												
K	2014	Cheyenne	Body	Amplifier																																																													
K	2014	Cheyenne	Body	Media Disc Player																																																													
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																													
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																													

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2014	Cheyenne	Body	HVAC Control Module																																																										
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																										
K	2014	Cheyenne	Body	Parking Assist Control Module																																																										
K	2014	Cheyenne	Body	Frontview Camera Module																																																										
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																															
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
K	2014	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2014	Silverado	Chassis	Parking Brake Control Module																																																										
K	2014	Silverado	Chassis	Power Steering Control Module																														V	V																											
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2014	Silverado	Body	Body Control Module																																																										
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Silverado	Body	Passenger Presence Module																																																										
K	2014	Silverado	Body	Instrument Cluster																																																										
K	2014	Silverado	Body	Radio Control																																																										
K	2014	Silverado	Body	HVAC Control																																																										
K	2014	Silverado	Body	Radio																																																										
K	2014	Silverado	Body	Amplifier																																																										
K	2014	Silverado	Body	Media Disc Player																																																										
K	2014	Silverado	Body	Human Machine Interface Control Module																																																										
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2014	Silverado	Body	Parking Assist Control Module																																																										
K	2014	Silverado	Body	Frontview Camera Module																																																										
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																								V																		
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																										
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																										
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2014	Silverado HD	Chassis	Suspension Control Module																																																										
K	2014	Silverado HD	Body	Body Control Module																																																										
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Silverado HD	Body	Passenger Presence Module																																																										
K	2014	Silverado HD	Body	Instrument Cluster																																																										
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																										
K	2014	Silverado HD	Body	Base Radio																																																										
K	2014	Silverado HD	Body	Navigation Radio																																																										
K	2014	Silverado HD	Body	Uplevel Radio																																																										
K	2014	Silverado HD	Body	Amplifier																																																										
K	2014	Silverado HD	Body	Rear Audio Control Module																																																										
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																										
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																										
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Silverado HD	Body	Seat Memory Control Module																																																										
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																										
K	2014	Silverado HD	Body	Parking Assist Control Module																									V																																	
K	2014	Silverado HD	Body	Theft Deterrent Module																																																										
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																										
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																							V																																			
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																													V																													
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2014	Suburban	Chassis	Parking Brake Control Module																																																										
K	2014	Suburban	Chassis	Suspension Control Module																																																										
K	2014	Suburban	Body	Body Control Module																																																										
K	2014	Suburban	Body	Auxiliary Body Control Module																																																										
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Suburban	Body	Passenger Presence Module																																																										
K	2014	Suburban	Body	Instrument Cluster																																																										
K	2014	Suburban	Body	Base Radio																																																										
K	2014	Suburban	Body	Navigation Radio																																																										
K	2014	Suburban	Body	Uplevel Radio																																																										
K	2014	Suburban	Body	Amplifier																																																										
K	2014	Suburban	Body	Rear Audio Control Module																																																										
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																										
K	2014	Suburban	Body	Personal Audio Link Control Module																																																										
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Suburban	Body	Liftgate Control Module																																																										
K	2014	Suburban	Body	Seat Memory Control Module																																																										
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																										
K	2014	Suburban	Body	Assist Step Control Module																								V																																		
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																										
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																										
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																										
K	2014	Suburban	Body	Parking Assist Control Module																									V																																	
K	2014	Suburban	Body	Theft Deterrent Module																																																										
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																										
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																							V																																			
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																														V																												
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																														V																												
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																										
K	2014	Tahoe	Chassis	Suspension Control Module																																																										
K	2014	Tahoe	Body	Body Control Module																																																										
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																										
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2014	Tahoe	Body	Passenger Presence Module																																																										
K	2014	Tahoe	Body	Instrument Cluster																																																										
K	2014	Tahoe	Body	Base Radio																																																										
K	2014	Tahoe	Body	Navigation Radio																																																										
K	2014	Tahoe	Body	Uplevel Radio																																																										
K	2014	Tahoe	Body	Amplifier																																																										
K	2014	Tahoe	Body	Rear Audio Control Module																																																										
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																										
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																										
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																										
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																										
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																										
K	2014	Tahoe	Body	Liftgate Control Module																																																										
K	2014	Tahoe	Body	Seat Memory Control Module																																																										
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																										
K	2014	Tahoe	Body	Assist Step Control Module																								V																																		
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																										
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																										
K	2014	Tahoe	Body	Parking Assist Control Module																									V																																	
K	2014	Tahoe	Body	Theft Deterrent Module																																																										
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																												
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																	
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																													V																															
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																													V																															
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																															
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																															
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																												
K	2015	Cheyenne	Chassis	Power Steering Control Module																														V	V																													
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Cheyenne	Chassis	Suspension Control Module																																																												
K	2015	Cheyenne	Body	Body Control Module																																																												
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Cheyenne	Body	Passenger Presence Module																																																												
K	2015	Cheyenne	Body	Instrument Cluster																																																												
K	2015	Cheyenne	Body	Radio Controls																																																												
K	2015	Cheyenne	Body	HVAC Controls																																																												
K	2015	Cheyenne	Body	Radio																																																												
K	2015	Cheyenne	Body	Amplifier																																																												
K	2015	Cheyenne	Body	Media Disc Player																																																												
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																												
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																												
K	2015	Cheyenne	Body	HVAC Control Module																																																												
K	2015	Cheyenne	Body	Parking Assist Control Module																																																												
K	2015	Cheyenne	Body	Frontview Camera Module																																																												
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																								V																				
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																															
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																													V																														
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																													V																														
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
K	2015	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																										
K	2015	Silverado	Chassis	Power Steering Control Module																														V	V																												
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Silverado	Chassis	Suspension Control Module																																																										
K	2015	Silverado	Body	Body Control Module																																																										
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Silverado	Body	Passenger Presence Module																																																										
K	2015	Silverado	Body	Instrument Cluster																																																										
K	2015	Silverado	Body	Radio Controls																																																										
K	2015	Silverado	Body	HVAC Controls																																																										
K	2015	Silverado	Body	Radio																																																										
K	2015	Silverado	Body	Amplifier																																																										
K	2015	Silverado	Body	Media Disc Player																																																										
K	2015	Silverado	Body	Human Machine Interface Control Module																																																										
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																																										
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2015	Silverado	Body	Parking Assist Control Module																																																										
K	2015	Silverado	Body	Frontview Camera Module																																																										
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																										
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																							V					V																														
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																													V																														
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
K	2015	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
K	2015	Suburban	Chassis	Parking Brake Control Module																																																										
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																										
K	2015	Suburban	Chassis	Power Steering Control Module																														V	V																												
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2015	Suburban	Chassis	Suspension Control Module																																																										
K	2015	Suburban	Body	Body Control Module																																																										
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2015	Suburban	Body	Passenger Presence Module																																																										
K	2015	Suburban	Body	Instrument Cluster																																																										
K	2015	Suburban	Body	Radio Controls																																																										
K	2015	Suburban	Body	HVAC Controls																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2015	Suburban	Body	Radio																																																											
K	2015	Suburban	Body	Amplifier																																																											
K	2015	Suburban	Body	Media Disc Player																																																											
K	2015	Suburban	Body	Human Machine Interface Control Module																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2015	Suburban	Body	HVAC Control Module																																																											
K	2015	Suburban	Body	Liftgate Control Module																																																											
K	2015	Suburban	Body	Keyless Entry Control Module																																																											
K	2015	Suburban	Body	Assist Step Control Module																																																											
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																											
K	2015	Suburban	Body	Parking Assist Control Module																																																											
K	2015	Suburban	Body	Frontview Camera Module																																																											
K	2015	Suburban	Body	Steering Column Lock Control Module																																																											
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																							V					V																															
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																													V																														
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																											
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																											
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																											
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																											
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																											
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																											
K	2015	Tahoe	Chassis	Power Steering Control Module																														V	V																												
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Tahoe	Chassis	Suspension Control Module																																																											
K	2015	Tahoe	Body	Body Control Module																																																											
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Tahoe	Body	Passenger Presence Module																																																											
K	2015	Tahoe	Body	Instrument Cluster																																																											
K	2015	Tahoe	Body	Radio Controls																																																											
K	2015	Tahoe	Body	HVAC Controls																																																											
K	2015	Tahoe	Body	Radio																																																											
K	2015	Tahoe	Body	Amplifier																																																											
K	2015	Tahoe	Body	Media Disc Player																																																											
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																											
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2015	Tahoe	Body	HVAC Control Module																																																											
K	2015	Tahoe	Body	Liftgate Control Module																																																											
K	2015	Tahoe	Body	Keyless Entry Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2015	Tahoe	Body	Assist Step Control Module																																																										
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2015	Tahoe	Body	Parking Assist Control Module																																																										
K	2015	Tahoe	Body	Frontview Camera Module																																																										
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																										
K	2015	Tahoe	Body	Battery Energy Control Module																																																										
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																														V																												
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																														V																												
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																														V																												
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																										
K	2016	Cheyenne	Chassis	Power Steering Control Module																															V	V																										
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Cheyenne	Chassis	Suspension Control Module																																																										
K	2016	Cheyenne	Body	Body Control Module																																																										
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Cheyenne	Body	Passenger Presence Module																																																										
K	2016	Cheyenne	Body	Instrument Cluster																																																										
K	2016	Cheyenne	Body	Radio Controls																																																										
K	2016	Cheyenne	Body	HVAC Controls																																																										
K	2016	Cheyenne	Body	Radio																																																										
K	2016	Cheyenne	Body	Amplifier																																																										
K	2016	Cheyenne	Body	Media Disc Player																																																										
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																										
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
K	2016	Cheyenne	Body	HVAC Control Module																																																										
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																										
K	2016	Cheyenne	Body	Parking Assist Control Module																																																										
K	2016	Cheyenne	Body	Frontview Camera Module																																																										
K	2016	Cheyenne	Body	Frontview Camera Module																																																										
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																								V																		
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																													V																													
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
K	2016	Silverado	Chassis	Electronic Brake Control Module																																																										
K	2016	Silverado	Chassis	Power Steering Control Module																																																										
K	2016	Silverado	Chassis	Power Steering Control Module																														V	V																											
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Silverado	Chassis	Suspension Control Module																																																										
K	2016	Silverado	Body	Body Control Module																																																										
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Silverado	Body	Passenger Presence Module																																																										
K	2016	Silverado	Body	Instrument Cluster																																																										
K	2016	Silverado	Body	Radio Controls																																																										
K	2016	Silverado	Body	HVAC Controls																																																										
K	2016	Silverado	Body	Radio (IO3)																																																										
K	2016	Silverado	Body	Radio (IOB)																																																										
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
K	2016	Silverado	Body	Amplifier																																																										
K	2016	Silverado	Body	Media Disc Player																																																										
K	2016	Silverado	Body	Human Machine Interface Control Module																																																										
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																										
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																										
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																										
K	2016	Silverado	Body	Parking Assist Control Module																																																										
K	2016	Silverado	Body	Frontview Camera Module																																																										
K	2016	Silverado	Body	Frontview Camera Module																																																										
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
K	2016	Suburban	Chassis	Electronic Brake Control Module																																																										
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
K	2016	Suburban	Chassis	Parking Brake Control Module																																																										
K	2016	Suburban	Chassis	Power Steering Control Module																														V	V																											
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Suburban	Chassis	Suspension Control Module																																																										
K	2016	Suburban	Body	Body Control Module																																																										
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2016	Suburban	Body	Passenger Presence Module																																																										
K	2016	Suburban	Body	Instrument Cluster																																																										
K	2016	Suburban	Body	Radio Controls																																																										
K	2016	Suburban	Body	HVAC Controls																																																										
K	2016	Suburban	Body	Radio																																																										
K	2016	Suburban	Body	Amplifier																																																										
K	2016	Suburban	Body	Media Disc Player																																																										
K	2016	Suburban	Body	Human Machine Interface Control Module																																																										
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																																										
K	2016	Suburban	Body	HVAC Control Module																																																										
K	2016	Suburban	Body	Liftgate Control Module																																																										
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																										
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																										
K	2016	Suburban	Body	Keyless Entry Control Module																																																										
K	2016	Suburban	Body	Assist Step Control Module																																																										
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																										
K	2016	Suburban	Body	Parking Assist Control Module																																																										
K	2016	Suburban	Body	Frontview Camera Module																																																										
K	2016	Suburban	Body	Steering Column Lock Control Module																																																										
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																																										
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																										
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																										
K	2016	Tahoe	Chassis	Power Steering Control Module																														V	V																											
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Tahoe	Chassis	Suspension Control Module																																																										
K	2016	Tahoe	Body	Body Control Module																																																										
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Tahoe	Body	Passenger Presence Module																																																										
K	2016	Tahoe	Body	Instrument Cluster																																																										
K	2016	Tahoe	Body	Radio Controls																																																										
K	2016	Tahoe	Body	HVAC Controls																																																										
K	2016	Tahoe	Body	Radio																																																										
K	2016	Tahoe	Body	Amplifier																																																										
K	2016	Tahoe	Body	Media Disc Player																																																										
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																										
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																										
K	2016	Tahoe	Body	HVAC Control Module																																																										
K	2016	Tahoe	Body	Liftgate Control Module																																																										
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																										
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																										
K	2016	Tahoe	Body	Keyless Entry Control Module																																																										
K	2016	Tahoe	Body	Assist Step Control Module																																																										
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2016	Tahoe	Body	Parking Assist Control Module																																																										
K	2016	Tahoe	Body	Frontview Camera Module																																																										
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
L	2004	ALL	Chassis	4WAL 3 Sensor																																																												
L	2004	ALL	Body	Body Control Module																																																											
L	2004	ALL	Body	Instrument Panel Cluster																																																											
L	2004	ALL	Body	Supplemental Inflatable Restraint		V																																																									
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
L	2005	Astro	Chassis	4WAL 3 Sensor																																																											
L	2005	Astro	Body	Body Control Module																																																										
L	2005	Astro	Body	Instrument Panel Cluster																																																										
L	2005	Astro	Body	Supplemental Inflatable Restraint																																																										
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																																										
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																																										
L	2005	Equinox	Chassis	Electric Power Steering																																																										
L	2005	Equinox	Body	Body Control Module																																																										
L	2005	Equinox	Body	Instrument Panel Cluster																																																										
L	2005	Equinox	Body	Radio																																																										
L	2005	Equinox	Body	Supplemental Inflatable Restraint		V																																																								
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2006	ALL	Chassis	Traction Control Yes																																																										
L	2006	ALL	Chassis	Traction Control No																																																										
L	2006	ALL	Chassis	Electric Power Steering																																																										
L	2006	ALL	Body	Body Control Module																																																										
L	2006	ALL	Body	Instrument Panel Cluster																																																										
L	2006	ALL	Body	Radio																																																										
L	2006	ALL	Body	Supplemental Inflatable Restraint		V																																																								
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																																										
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																																										
L	2007	ALL	Chassis	Power Steering Control Module																																																										
L	2007	ALL	Body	Body Control Module																																																										
L	2007	ALL	Body	Digital Radio Receiver																																																										
L	2007	ALL	Body	Heated Seat Module																																																										
L	2007	ALL	Body	HVAC Control Module																																																										
L	2007	ALL	Body	Instrument Panel Cluster																																																										
L	2007	ALL	Body	Passenger Presence System																																																										
L	2007	ALL	Body	Radio																																																										
L	2007	ALL	Body	Rollover Sensor																																																										
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2007	ALL	Body	Theft Deterrent Module																																																										
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2008	Captiva Sport	Body	Body Control Module																																																										
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																										
L	2008	Captiva Sport	Body	HVAC Control Module Auto																																																										
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																																										
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2008	Captiva Sport	Body	Passenger Presence System																																																										
L	2008	Captiva Sport	Body	Radio																																																										
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2008	Captiva Sport	Body	Rollover Sensor																																																										
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2008	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																										
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2008	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2008	Equinox	Chassis	Power Steering Control Module																																																										
L	2008	Equinox	Body	Body Control Module																																																										
L	2008	Equinox	Body	Digital Radio Receiver																																																										
L	2008	Equinox	Body	Heated Seat Module																																																										
L	2008	Equinox	Body	HVAC Control Module																																																										
L	2008	Equinox	Body	Instrument Panel Cluster																																																										
L	2008	Equinox	Body	Passenger Presence System																																																										
L	2008	Equinox	Body	Radio																																																										
L	2008	Equinox	Body	Rollover Sensor																																																										
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																																										
L	2008	Equinox	Body	Theft Deterrent Module																																																										
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																										
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																										
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																										
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																																										
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																										
L	2009	Captiva Sport	Body	Body Control Module																																																										
L	2009	Captiva Sport	Body	HVAC Control Module Auto																																																										
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																																										
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																																										
L	2009	Captiva Sport	Body	Passenger Presence System																																																										
L	2009	Captiva Sport	Body	Radio																																																										
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2009	Captiva Sport	Body	Rollover Sensor																																																										
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2009	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																											
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																												
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																												
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																												
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
L	2009	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2009	Equinox	Chassis	Power Steering Control Module																																																												
L	2009	Equinox	Body	Body Control Module																																																												
L	2009	Equinox	Body	Digital Radio Receiver																																																												
L	2009	Equinox	Body	Heated Seat Module																																																												
L	2009	Equinox	Body	HVAC Control Module																																																												
L	2009	Equinox	Body	Instrument Panel Cluster																																																												
L	2009	Equinox	Body	Passenger Presence System																																																												
L	2009	Equinox	Body	Radio																																																											
L	2009	Equinox	Body	Rollover Sensor																																																											
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																																											
L	2009	Equinox	Body	Theft Deterrent Module																																																											
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																											
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																											
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																											
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																											
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																											
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																											
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																											
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																											
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																											
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																											
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																																											
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																											
L	2010	Captiva Sport	Body	Body Control Module																																																											
L	2010	Captiva Sport	Body	HVAC Control Module																																																											
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																																											
L	2010	Captiva Sport	Body	Passenger Presence System																																																											
L	2010	Captiva Sport	Body	Radio																																																										
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2010	Captiva Sport	Body	Rollover Sensor																																																										
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2010	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																										
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																										
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																										
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2010	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2010	Equinox	Body	Body Control Module																																																										
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2010	Equinox	Body	Passenger Presence Module																																																										
L	2010	Equinox	Body	Instrument Cluster																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2010	Equinox	Body	Radio																																																											
L	2010	Equinox	Body	Multimedia Player Interface Module																																																												
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2010	Equinox	Body	Liftgate Control Module																																																												
L	2010	Equinox	Body	Parking Assist Control Module																																																												
L	2010	Equinox	Body	Frontview Camera Module																																																												
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																																												
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
L	2011	Captiva	Chassis	Electronic Brake Control Module																																																												
L	2011	Captiva	Chassis	Parking Brake Control Module																																																												
L	2011	Captiva	Body	Body Control Module																																																												
L	2011	Captiva	Body	Auxiliary Body Control Module																																																												
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2011	Captiva	Body	Instrument Cluster																																																												
L	2011	Captiva	Body	Headlamp Control Module																																																												
L	2011	Captiva	Body	HVAC Control Module																																																												
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																												
L	2011	Captiva	Body	Parking Assist Control Module																										V																																		
L	2011	Captiva	Body	Theft Deterrent Module																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module																																																												
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																																												
L	2011	Captiva Sport	Body	Body Control Module																																																												
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																												
L	2011	Captiva Sport	Body	HVAC Control Module																																																												
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																																												
L	2011	Captiva Sport	Body	Passenger Presence System																																																												
L	2011	Captiva Sport	Body	Radio																																																												
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																																												
L	2011	Captiva Sport	Body	Rollover Sensor																																																												
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																																																												
L	2011	Captiva Sport	Body	Theft Deterrent Module																																																												
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																																												
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																												
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																												
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																												
L	2011	Equinox	Chassis	Electronic Brake Control Module																																																												
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2011	Equinox	Body	Body Control Module																																																												
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2011	Equinox	Body	Passenger Presence Module																																																												
L	2011	Equinox	Body	Instrument Cluster																																																												
L	2011	Equinox	Body	Radio																																																												
L	2011	Equinox	Body	Multimedia Player Interface Module																																																												
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2011	Equinox	Body	Liftgate Control Module																																																												
L	2011	Equinox	Body	Parking Assist Control Module																																																												
L	2011	Equinox	Body	Frontview Camera Module																																																												
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																																																												
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																												
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																												
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																												
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																												
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																												
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																												
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
L	2012	Captiva	Chassis	Electronic Brake Control Module																																																											
L	2012	Captiva	Chassis	Parking Brake Control Module																																																											
L	2012	Captiva	Body	Body Control Module																																																											
L	2012	Captiva	Body	Auxiliary Body Control Module																																																											
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2012	Captiva	Body	Instrument Cluster																																																											
L	2012	Captiva	Body	Headlamp Control Module																																																											
L	2012	Captiva	Body	HVAC Control Module																																																											
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																											
L	2012	Captiva	Body	Parking Assist Control Module																									V																																		
L	2012	Captiva	Body	Theft Deterrent Module																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																											
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module																																																											
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																																											
L	2012	Captiva Sport	Body	Body Control Module																																																											
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																											
L	2012	Captiva Sport	Body	HVAC Control Module																																																											
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																																											
L	2012	Captiva Sport	Body	Passenger Presence System																																																											
L	2012	Captiva Sport	Body	Radio																																																											
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																																											
L	2012	Captiva Sport	Body	Rollover Sensor																																																											
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																																																											
L	2012	Captiva Sport	Body	Theft Deterrent Module																																																											
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																											
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																											
L	2012	Equinox	Chassis	Electronic Brake Control Module																																																											
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2012	Equinox	Body	Body Control Module																																																											
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2012	Equinox	Body	Passenger Presence Module																																																											
L	2012	Equinox	Body	Instrument Cluster																																																											
L	2012	Equinox	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2012	Equinox	Body	Multimedia Player Interface Module																																																											
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											
L	2012	Equinox	Body	Liftgate Control Module																																																											
L	2012	Equinox	Body	Parking Assist Control Module																																																											
L	2012	Equinox	Body	Frontview Camera Module																																																											
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																																											
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																											
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																											
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																											
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																											
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																											
L	2013	Captiva	Chassis	Parking Brake Control Module																																																											
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																											
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																											
L	2013	Captiva	Body	Auxiliary Body Control Module																																																											
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2013	Captiva	Body	Instrument Cluster																																																											
L	2013	Captiva	Body	Headlamp Control Module																																																											
L	2013	Captiva	Body	HVAC Control Module																																																											
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																											
L	2013	Captiva	Body	Theft Deterrent Module																																																											
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																											
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																											
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																											
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																											
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																											
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																											
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																																											
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																											
L	2013	Captiva Sport	Body	Body Control Module																																																											
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																											
L	2013	Captiva Sport	Body	Heated Seat Module																																																											
L	2013	Captiva Sport	Body	HVAC Control Module																																																											
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2013	Captiva Sport	Body	Park Assist Module																																																										
L	2013	Captiva Sport	Body	Passenger Presence System																																																										
L	2013	Captiva Sport	Body	Radio																																																										
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																										
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																																										
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																										
L	2013	Captiva Sport	Body	Theft Deterrent Module																																																										
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2013	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2013	Equinox	Chassis	Power Steering Control Module																																																										
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2013	Equinox	Body	Passenger Presence Module																																																										
L	2013	Equinox	Body	Instrument Cluster																																																										
L	2013	Equinox	Body	Radio																																																										
L	2013	Equinox	Body	Rear Audio Control Module																																																										
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2013	Equinox	Body	Liftgate Control Module																																																										
L	2013	Equinox	Body	Front Seat Heating Control Module																																																										
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2013	Equinox	Body	Parking Assist Control Module																																																										
L	2013	Equinox	Body	Frontview Camera Module																																																										
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2014	Captiva (3GN)	Body	Body Control Module																																																										
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																										
L	2014	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2014	Captiva (3GN)	Body	Radio																																																										
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																										
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																										
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																														
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																									V																																					
L	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																														
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																														
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																														
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																														
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																														
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																														
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																														
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																														
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																														
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																														
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																														
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																														
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																														
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																														
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																														
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																														
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																														
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																														
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																														
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																														
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																														
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																														
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2014	Captiva (Other)	Body	Instrument Cluster																																																														
L	2014	Captiva (Other)	Body	Headlamp Control Module																																																														
L	2014	Captiva (Other)	Body	HVAC Control Module																																																														
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																														
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																														
L	2014	Captiva (Other)	Body	Theft Deterrent Module																																																														
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																														
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																														
L	2014	Equinox	Chassis	Electronic Brake Control Module																																																														
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2014	Equinox	Chassis	Power Steering Control Module																																																														
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																														
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																														
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2014	Equinox	Body	Passenger Presence Module																																																														
L	2014	Equinox	Body	Instrument Cluster																																																														
L	2014	Equinox	Body	Radio																																																														
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																														
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																														
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																														
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																														

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2014	Equinox	Body	Liftgate Control Module																																																												
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																												
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																												
L	2014	Equinox	Body	Parking Assist Control Module																																																												
L	2014	Equinox	Body	Frontview Camera Module																																																												
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																												
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																												
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																												
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																												
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																												
L	2015	Captiva (3GN)	Body	Body Control Module																																																												
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																																												
L	2015	Captiva (3GN)	Body	Instrument Cluster																																																												
L	2015	Captiva (3GN)	Body	Radio																																																												
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																												
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																												
L	2015	Captiva (3GN)	Body	HVAC Control Module																																																												
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																									V																																			
L	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																												
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																												
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																												
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																												
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																												
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																												
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																												
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																												
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																												
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																												
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2015	Captiva (Other)	Body	Instrument Cluster																																																												
L	2015	Captiva (Other)	Body	Headlamp Control Module																																																												
L	2015	Captiva (Other)	Body	HVAC Control Module																																																												
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																									
L	2015	Captiva (Other)	Body	Theft Deterrent Module																																																										
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2015	Equinox	Chassis	Power Steering Control Module																																																										
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Equinox	Body	Passenger Presence Module																																																										
L	2015	Equinox	Body	Instrument Cluster																																																										
L	2015	Equinox	Body	Radio																																																										
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																																										
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2015	Equinox	Body	Liftgate Control Module																																																										
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2015	Equinox	Body	Parking Assist Control Module																																																										
L	2015	Equinox	Body	Frontview Camera Module																																																										
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																										
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																										
L	2016	Captiva (3GN)	Body	Body Control Module																																																										
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Captiva (3GN)	Body	Instrument Cluster																																																										
L	2016	Captiva (3GN)	Body	Radio																																																										
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																										
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																										
L	2016	Captiva (3GN)	Body	HVAC Control Module																																																										
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																										
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																										
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																										
L	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																										
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																									
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Captiva (Other)	Body	Instrument Cluster																																																										
L	2016	Captiva (Other)	Body	Headlamp Control Module																																																										
L	2016	Captiva (Other)	Body	Radio																																																										
L	2016	Captiva (Other)	Body	HVAC Control Module																																																										
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																																										
L	2016	Captiva (Other)	Body	Theft Deterrent Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2016	Equinox	Chassis	Power Steering Control Module																																																										
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Equinox	Body	Passenger Presence Module																																																										
L	2016	Equinox	Body	Instrument Cluster																																																										
L	2016	Equinox	Body	Radio																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2016	Equinox	Body	Liftgate Control Module																																																										
L	2016	Equinox	Body	Seat Memory Control Module																																																										
L	2016	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Parking Assist Control Module																																																										
L	2016	Equinox	Body	Frontview Camera Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
M	2004	ALL	Chassis	4WAL 3 Sensor																																																											
M	2004	ALL	Body	Body Control Module																																																											
M	2004	ALL	Body	Instrument Panel Cluster																																																											
M	2004	ALL	Body	Supplemental Inflatable Restraint		V																																																									
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
M	2005	ALL	Chassis	4WAL 3 Sensor																																																											
M	2005	ALL	Body	Body Control Module																																																											
M	2005	ALL	Body	Instrument Panel Cluster																																																											
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2007	ALL	Body	Supplemental Inflatable Restraint			V																																																								
P	2007	ALL	Body	Theft Deterrent Module																																																											
R	2009	ALL	Powertrain	Engine Control Module																																																											
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2009	ALL	Powertrain	Transmission Control Module																																																											
R	2009	ALL	Chassis	Electronic Brake Control Module					V																																																						
R	2009	ALL	Body	Body Control Module																																																											
R	2009	ALL	Body	Digital Radio Receiver																																																											
R	2009	ALL	Body	Driver Door Switch																																																											
R	2009	ALL	Body	Heated Seat Module																																																											
R	2009	ALL	Body	HVAC Control Module Auto						V																																																					
R	2009	ALL	Body	HVAC Control Module Manual						V																																																					
R	2009	ALL	Body	Instrument Panel Cluster																																																											
R	2009	ALL	Body	Lift Gate Module																																																											
R	2009	ALL	Body	Park Assist Module								V																																																		
R	2009	ALL	Body	Passenger Door Switch																																																											
R	2009	ALL	Body	Passenger Presence System																																																											
R	2009	ALL	Body	Radio																																																											
R	2009	ALL	Body	Rear HVAC/RSA																																																											
R	2009	ALL	Body	Rollover Sensor																																																											
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2009	ALL	Body	Theft Deterrent Module																																																											
R	2010	ALL	Powertrain	Engine Control Module																																																											
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2010	ALL	Powertrain	Transmission Control Module																																																											
R	2010	ALL	Chassis	Electronic Brake Control Module					V																																																						
R	2010	ALL	Body	Body Control Module																																																											
R	2010	ALL	Body	Digital Radio Receiver																																																											
R	2010	ALL	Body	Driver Door Switch																																																											
R	2010	ALL	Body	Heated Seat Module																																																											
R	2010	ALL	Body	HVAC Control Module Auto						V																																																					
R	2010	ALL	Body	HVAC Control Module Manual						V																																																					
R	2010	ALL	Body	Instrument Panel Cluster																																																											
R	2010	ALL	Body	Lift Gate Module																																																											
R	2010	ALL	Body	Park Assist Module																																																											
R	2010	ALL	Body	Passenger Door Switch																																																											
R	2010	ALL	Body	Passenger Presence System																																																											
R	2010	ALL	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
R	2010	ALL	Body	Rear HVAC/RSA																																																										
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2010	ALL	Body	Theft Deterrent Module																																																										
R	2011	ALL	Powertrain	Engine Control Module																																																										
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2011	ALL	Powertrain	Transmission Control Module																																																										
R	2011	ALL	Chassis	Electronic Brake Control Module					V																																																					
R	2011	ALL	Body	Body Control Module																																																										
R	2011	ALL	Body	Digital Radio Receiver																																																										
R	2011	ALL	Body	Driver Door Switch																																																										
R	2011	ALL	Body	Heated Seat Module																																																										
R	2011	ALL	Body	HVAC Control Module Auto						V																																										V										
R	2011	ALL	Body	HVAC Control Module Manual						V																																																				
R	2011	ALL	Body	Instrument Panel Cluster																																																										
R	2011	ALL	Body	Lift Gate Module																																																										
R	2011	ALL	Body	Park Assist Module																																																										
R	2011	ALL	Body	Passenger Door Switch																																																										
R	2011	ALL	Body	Passenger Presence System																																																										
R	2011	ALL	Body	Radio																																																										
R	2011	ALL	Body	Rear HVAC/RSA																																																										
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2011	ALL	Body	Theft Deterrent Module																																																										
R	2012	ALL	Powertrain	Engine Control Module																																																										
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2012	ALL	Powertrain	Transmission Control Module																																																										
R	2012	ALL	Chassis	Electronic Brake Control Module					V																																																					
R	2012	ALL	Body	Body Control Module																																																										
R	2012	ALL	Body	Digital Radio Receiver																																																										
R	2012	ALL	Body	Driver Door Switch																																																										
R	2012	ALL	Body	Heated Seat Module																																																										
R	2012	ALL	Body	HVAC Control Module Auto						V																																										V										
R	2012	ALL	Body	HVAC Control Module Manual						V																																																				
R	2012	ALL	Body	Instrument Panel Cluster																																																										
R	2012	ALL	Body	Lift Gate Module																																																										
R	2012	ALL	Body	Park Assist Module																																																										
R	2012	ALL	Body	Passenger Door Switch																																																										
R	2012	ALL	Body	Passenger Presence System																																																										
R	2012	ALL	Body	Radio																																																										
R	2012	ALL	Body	Rear HVAC/RSA																																																										
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2012	ALL	Body	Theft Deterrent Module																																																										
R	2013	ALL	Powertrain	Engine Control Module																																																										
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2013	ALL	Powertrain	Transmission Control Module																																																										
R	2013	ALL	Chassis	Electronic Brake Control Module					V																																																					
R	2013	ALL	Body	Body Control Module																																																										
R	2013	ALL	Body	Digital Radio Receiver																																																										
R	2013	ALL	Body	Driver Door Switch																																																										
R	2013	ALL	Body	Heated Seat Module																																																										
R	2013	ALL	Body	HVAC Control Module Auto						V																																										V										
R	2013	ALL	Body	HVAC Control Module Manual						V																																																				

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
R	2013	ALL	Body	Instrument Panel Cluster																																																												
R	2013	ALL	Body	Left Side Object Detection Module																																																												
R	2013	ALL	Body	Lift Gate Module																																																												
R	2013	ALL	Body	Park Assist Module																																																											
R	2013	ALL	Body	Passenger Door Switch																																																											
R	2013	ALL	Body	Passenger Presence System																																																											
R	2013	ALL	Body	Radio																																																											
R	2013	ALL	Body	Rear HVAC/RSA																																																											
R	2013	ALL	Body	Right Side Object Detection Module																																																											
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2013	ALL	Body	Theft Deterrent Module																																																											
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
R	2014	Traverse	Powertrain	Chassis Control Module																																																											
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																											
R	2014	Traverse	Chassis	Electronic Brake Control Module																																																											
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																											
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																											
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2014	Traverse	Body	Passenger Presence Module																																																											
R	2014	Traverse	Body	Instrument Cluster																																																											
R	2014	Traverse	Body	Radio																																																											
R	2014	Traverse	Body	Rear Audio Control Module																																																											
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																											
R	2014	Traverse	Body	Personal Audio Link Control Module																																																											
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																											
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																											
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																											
R	2014	Traverse	Body	Liftgate Control Module																																																											
R	2014	Traverse	Body	Seat Memory Control Module																																																											
R	2014	Traverse	Body	Front Seat Heating Control Module																																																											
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																											
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																											
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																											
R	2014	Traverse	Body	Parking Assist Control Module																																																											
R	2014	Traverse	Body	Frontview Camera Module																																																											
R	2014	Traverse	Body	Theft Deterrent Module																																																											
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																											
R	2015	Traverse	Chassis	Electronic Brake Control Module																																																											
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																											
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																											
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2015	Traverse	Body	Passenger Presence Module																																																											
R	2015	Traverse	Body	Instrument Cluster																																																											
R	2015	Traverse	Body	Radio																																																											
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																											
R	2015	Traverse	Body	Liftgate Control Module																																																											
R	2015	Traverse	Body	Seat Memory Control Module																																																											
R	2015	Traverse	Body	Front Seat Heating Control Module																																																											
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																											
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																											
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																											
R	2015	Traverse	Body	Parking Assist Control Module																																																											
R	2015	Traverse	Body	Frontview Camera Module																																																											
R	2015	Traverse	Body	Theft Deterrent Module																																																											
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																											
R	2016	Traverse	Chassis	Electronic Brake Control Module																																																											
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																											
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																											
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2016	Traverse	Body	Passenger Presence Module																																																											
R	2016	Traverse	Body	Instrument Cluster																																																											
R	2016	Traverse	Body	Radio																																																											
R	2016	Traverse	Body	Rear Audio Control Module																																																											
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																											
R	2016	Traverse	Body	Personal Audio Link Control Module																																																											
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																											
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																											
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																											
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																											
R	2016	Traverse	Body	Liftgate Control Module																																																											
R	2016	Traverse	Body	Seat Memory Control Module																																																											
R	2016	Traverse	Body	Front Seat Heating Control Module																																																											
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																											
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																											
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																											
R	2016	Traverse	Body	Parking Assist Control Module																																																											
R	2016	Traverse	Body	Frontview Camera Module																																																											
R	2016	Traverse	Body	Theft Deterrent Module																																																											
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2004	S10	Chassis	4WAL 3 Sensor																																																											
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																											
S	2004	S10	Body	Body Control Module																																																											
S	2004	S10	Body	Instrument Panel Cluster																																																											
S	2004	S10	Body	Base Radio																																																											
S	2004	S10	Body	Uplevel Radio																																																											
S	2004	S10	Body	Supplemental Inflatable Restraint		V																																																									
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2004	Colorado	Chassis	ABS Without Traction Control																																																											
S	2004	Colorado	Chassis	ABS With Traction Control																																																											
S	2004	Colorado	Body	Body Control Module																																																											
S	2004	Colorado	Body	Instrument Panel Cluster																																																											
S	2004	Colorado	Body	OnStar																																																											
S	2004	Colorado	Body	Base Radio																																																											
S	2004	Colorado	Body	Uplevel Radio																																																											
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																																											
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																											
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																											
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																											
S	2004	TrailBlazer	Body	Body Control Module																																																											
S	2004	TrailBlazer	Body	Driver Door Module																																																											
S	2004	TrailBlazer	Body	Driver Seat Module																																																											
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																											
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																											
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																																											
S	2004	TrailBlazer	Body	Lift Gate Module																																																											
S	2004	TrailBlazer	Body	OnStar																																																											
S	2004	TrailBlazer	Body	Passenger Door Module																																																											
S	2004	TrailBlazer	Body	Uplevel Radio																																																											
S	2004	TrailBlazer	Body	Navigation Radio																																																											
S	2004	TrailBlazer	Body	Rear Seat Audio																																																											
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																											
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint		V																																																								
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																											
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																											
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																											
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																											
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																											
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																											
S	2004	TrailBlazer EXT	Body	Body Control Module																																																											
S	2004	TrailBlazer EXT	Body	Driver Door Module																																																											
S	2004	TrailBlazer EXT	Body	Driver Seat Module																																																											
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																											
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																											
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																											
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																											
S	2004	TrailBlazer EXT	Body	OnStar																																																											
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																																											
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																											
S	2004	TrailBlazer EXT	Body	Navigation Radio																																																											
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																											
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																											
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint		V																																																									
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																											
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																											
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Blazer	Body	Body Control Module																																																											
S	2004	Blazer	Body	Heating and Air Conditioning																																																											
S	2004	Blazer	Body	Instrument Panel Cluster																																																											
S	2004	Blazer	Body	Memory Seat Module																																																											
S	2004	Blazer	Body	Base Radio																																																											
S	2004	Blazer	Body	Uplevel Radio																																																											
S	2004	Blazer	Body	Supplemental Inflatable Restraint		V																																																									
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																											
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																											
S	2004	SSR	Chassis	4WAL 3 Sensor																																																											
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																											
S	2004	SSR	Body	Amplifier (Bose)																																																											
S	2004	SSR	Body	Body Control Module																																																											
S	2004	SSR	Body	Driver Seat Module																																																											
S	2004	SSR	Body	Instrument Panel Cluster																																																											
S	2004	SSR	Body	Uplevel Radio																																																											
S	2004	SSR	Body	Remote Function Actuation																																																											
S	2004	SSR	Body	Roof and Door Module																																																											
S	2004	SSR	Body	Supplemental Inflatable Restraint		V																																																									
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2005	Colorado	Chassis	ABS Without Traction Control																																																											
S	2005	Colorado	Chassis	ABS With Traction Control																																																											
S	2005	Colorado	Body	Body Control Module																																																											
S	2005	Colorado	Body	Instrument Panel Cluster																																																											
S	2005	Colorado	Body	Base Radio																																																											
S	2005	Colorado	Body	Uplevel Radio																																																											
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																																											
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																																											
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																											
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																											
S	2005	TrailBlazer	Body	Body Control Module																																																											
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																											
S	2005	TrailBlazer	Body	Driver Door Module																																																											
S	2005	TrailBlazer	Body	Driver Seat Module																																																											
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																											
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																											
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2005	TrailBlazer	Body	Lift Gate Module																																																										
S	2005	TrailBlazer	Body	Passenger Door Module																																																										
S	2005	TrailBlazer	Body	Passenger Presence System																																																										
S	2005	TrailBlazer	Body	Uplevel Radio																																																										
S	2005	TrailBlazer	Body	Navigation Radio																																																										
S	2005	TrailBlazer	Body	Rear Seat Audio																																																										
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																										
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																										
S	2005	TrailBlazer EXT	Body	Body Control Module																																																										
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
S	2005	TrailBlazer EXT	Body	Driver Door Module																																																										
S	2005	TrailBlazer EXT	Body	Driver Seat Module																																																										
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																										
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																										
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																										
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																										
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																																										
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																										
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																										
S	2005	TrailBlazer EXT	Body	Navigation Radio																																																										
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																										
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																										
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																										
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																										
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																										
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																										
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																										
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Blazer	Body	Body Control Module																																																										
S	2005	Blazer	Body	Heating and Air Conditioning																																																										
S	2005	Blazer	Body	Instrument Panel Cluster																																																										
S	2005	Blazer	Body	Memory Seat Module																																																										
S	2005	Blazer	Body	Base Radio																																																										
S	2005	Blazer	Body	Uplevel Radio																																																										
S	2005	Blazer	Body	Supplemental Inflatable Restraint		V																																																								
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2005	SSR	Chassis	4WAL 3 Sensor																																																										
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																										
S	2005	SSR	Body	Amplifier (Bose)																																																										
S	2005	SSR	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2005	SSR	Body	Driver Seat Module																																																										
S	2005	SSR	Body	Instrument Panel Cluster																																																										
S	2005	SSR	Body	Uplevel Radio																																																										
S	2005	SSR	Body	Remote Function Actuation																																																										
S	2005	SSR	Body	Roof and Door Module																																																										
S	2005	SSR	Body	Supplemental Inflatable Restraint		V																																																								
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2006	Colorado	Chassis	ABS Without Traction Control																																																										
S	2006	Colorado	Chassis	ABS With Traction Control																																																										
S	2006	Colorado	Body	Body Control Module																																																										
S	2006	Colorado	Body	Instrument Panel Cluster																																																										
S	2006	Colorado	Body	Passenger Presence System																																																										
S	2006	Colorado	Body	Base Radio																																																										
S	2006	Colorado	Body	Uplevel Radio																																																										
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																																										
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																																										
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																										
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																										
S	2006	TrailBlazer	Body	Body Control Module																																																										
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																										
S	2006	TrailBlazer	Body	Driver Door Module																																																										
S	2006	TrailBlazer	Body	Driver Seat Module																																																										
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																										
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																										
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																																										
S	2006	TrailBlazer	Body	Lift Gate Module																																																										
S	2006	TrailBlazer	Body	Passenger Door Module																																																										
S	2006	TrailBlazer	Body	Passenger Presence System																																																										
S	2006	TrailBlazer	Body	Uplevel Radio																																																										
S	2006	TrailBlazer	Body	Navigation Radio																																																										
S	2006	TrailBlazer	Body	Rear Seat Audio																																																										
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																										
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																										
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																										
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																										
S	2006	TrailBlazer EXT	Body	Body Control Module																																																										
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																										
S	2006	TrailBlazer EXT	Body	Driver Door Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2006	TrailBlazer EXT	Body	Driver Seat Module																																																												
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																												
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																												
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																												
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																												
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																																												
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																												
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																												
S	2006	TrailBlazer EXT	Body	Navigation Radio																																																												
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																												
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																												
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																												
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																												
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																												
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																												
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2006	SSR	Chassis	4WAL 3 Sensor																																																												
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																												
S	2006	SSR	Body	Amplifier (Bose)																																																												
S	2006	SSR	Body	Body Control Module																																																												
S	2006	SSR	Body	Driver Seat Module																																																												
S	2006	SSR	Body	Instrument Panel Cluster																																																												
S	2006	SSR	Body	Uplevel Radio																																																												
S	2006	SSR	Body	Remote Function Actuation																																																												
S	2006	SSR	Body	Roof and Door Module																																																												
S	2006	SSR	Body	Supplemental Inflatable Restraint																																																												
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2007	Colorado	Body	Body Control Module																																																												
S	2007	Colorado	Body	Digital Radio Receiver																																																												
S	2007	Colorado	Body	Generator Battery Control Module																																																												
S	2007	Colorado	Body	Instrument Panel Cluster																																																												
S	2007	Colorado	Body	Passenger Presence System																																																												
S	2007	Colorado	Body	Base Radio																																																												
S	2007	Colorado	Body	Uplevel Radio																																																												
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																																												
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																												
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																												
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2007	Trailblazer	Body	Body Control Module																																																												
S	2007	Trailblazer	Body	Digital Radio Receiver																																																												
S	2007	Trailblazer	Body	Disc Player and Video Display																																																												
S	2007	Trailblazer	Body	Driver Door Module																																																												
S	2007	Trailblazer	Body	Driver Seat Module																																																												
S	2007	Trailblazer	Body	Generator Battery Control Module																																																												
S	2007	Trailblazer	Body	HVAC Control Module Auto																																																												
S	2007	Trailblazer	Body	HVAC Control Module Manual																																																												
S	2007	Trailblazer	Body	Instrument Panel Cluster																																																												
S	2007	Trailblazer	Body	Lift Gate Module																																																												
S	2007	Trailblazer	Body	Passenger Door Module																																																												
S	2007	Trailblazer	Body	Passenger Presence System																																																												
S	2007	Trailblazer	Body	Uplevel Radio																																																												
S	2007	Trailblazer	Body	Navigation Radio																																																												
S	2007	Trailblazer	Body	Rear Seat Audio																																																												
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																												
S	2007	Trailblazer	Body	Theft Deterrent Module																																																												
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																												
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2008	Colorado	Body	Body Control Module																																																												
S	2008	Colorado	Body	Digital Radio Receiver																																																												
S	2008	Colorado	Body	Generator Battery Control Module																																																												
S	2008	Colorado	Body	Instrument Panel Cluster																																																												
S	2008	Colorado	Body	Passenger Presence System																																																												
S	2008	Colorado	Body	Base Radio																																																												
S	2008	Colorado	Body	Uplevel Radio																																																												
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2008	Colorado	Body	Theft Deterrent Module																																																												
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																																												
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
S	2008	TrailBlazer	Body	Body Control Module																																																												
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																												
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																												
S	2008	TrailBlazer	Body	Driver Door Module																																																												
S	2008	TrailBlazer	Body	Driver Seat Module																																																												
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																												
S	2008	TrailBlazer	Body	HVAC Control Module Auto																																																												
S	2008	TrailBlazer	Body	HVAC Control Module Manual																																																												
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2008	TrailBlazer	Body	Lift Gate Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2008	TrailBlazer	Body	Passenger Door Module																																																												
S	2008	TrailBlazer	Body	Passenger Presence System																																																												
S	2008	TrailBlazer	Body	Uplevel Radio																																																												
S	2008	TrailBlazer	Body	Navigation Radio																																																												
S	2008	TrailBlazer	Body	Rear Seat Audio																																																												
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
S	2008	TrailBlazer	Body	Theft Deterrent Module																																																												
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																												
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																												
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																												
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																												
S	2009	Colorado	Chassis	Electronic Brake Control Module																																																												
S	2009	Colorado	Body	Body Control Module																																																												
S	2009	Colorado	Body	Digital Radio Receiver																																																												
S	2009	Colorado	Body	Generator Battery Control Module																																																												
S	2009	Colorado	Body	Instrument Panel Cluster																																																												
S	2009	Colorado	Body	Passenger Presence System																																																												
S	2009	Colorado	Body	Base Radio																																																												
S	2009	Colorado	Body	Uplevel Radio																																																												
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																																												
S	2009	Colorado	Body	Theft Deterrent Module																																																												
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																												
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																												
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
S	2009	TrailBlazer	Body	Body Control Module																																																												
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																												
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																												
S	2009	TrailBlazer	Body	Driver Door Module																																																												
S	2009	TrailBlazer	Body	Driver Seat Module																																																												
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																												
S	2009	TrailBlazer	Body	HVAC Control Module Auto																																																												
S	2009	TrailBlazer	Body	HVAC Control Module Manual																																																												
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																																												
S	2009	TrailBlazer	Body	Lift Gate Module																																																												
S	2009	TrailBlazer	Body	Passenger Door Module																																																												
S	2009	TrailBlazer	Body	Passenger Presence System																																																												
S	2009	TrailBlazer	Body	Uplevel Radio																																																												
S	2009	TrailBlazer	Body	Navigation Radio																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2009	TrailBlazer	Body	Rear Seat Audio																																																												
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
S	2009	TrailBlazer	Body	Theft Deterrent Module																																																												
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																												V															
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																												V															
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																												V															
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
S	2010	ALL	Chassis	Electronic Brake Control Module																																																													
S	2010	ALL	Body	Body Control Module																																																												
S	2010	ALL	Body	Digital Radio Receiver																																																												
S	2010	ALL	Body	Generator Battery Control Module																																																												
S	2010	ALL	Body	Instrument Panel Cluster																																																												
S	2010	ALL	Body	Passenger Presence System																																																												
S	2010	ALL	Body	Personal Audio Link Module																																																												
S	2010	ALL	Body	Base Radio																																																												
S	2010	ALL	Body	Uplevel Radio																																																												
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
S	2010	ALL	Body	Theft Deterrent Module																																																												
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																												
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																												V															
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																												V															
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																												V															
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
S	2011	ALL	Chassis	Electronic Brake Control Module																																																													
S	2011	ALL	Body	Body Control Module																																																												
S	2011	ALL	Body	Digital Radio Receiver																																																												
S	2011	ALL	Body	Generator Battery Control Module																																																												
S	2011	ALL	Body	Instrument Panel Cluster																																																												
S	2011	ALL	Body	Passenger Presence System																																																												
S	2011	ALL	Body	Personal Audio Link Module																																																												
S	2011	ALL	Body	Base Radio																																																												
S	2011	ALL	Body	Uplevel Radio																																																												
S	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
S	2011	ALL	Body	Theft Deterrent Module																																																												
S	2011	ALL	Body	Vehicle Comm. Interface Module																																																												
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																												V															
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																												V															
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																									
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										V
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																										
S	2012	Colorado (First Gen)	Body	Body Control Module																																																										
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																										
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																										
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																										
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																										
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																										
S	2012	Colorado (First Gen)	Body	Base Radio																																																										
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																										
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																										
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																										
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																										
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																										
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																										
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2012	Colorado (Second Gen)	Body	Body Control Module																																																										
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																										
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																										
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																										
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																										
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																										
S	2012	S10	Powertrain	Transfer Case Control Module																																																										
S	2012	S10	Chassis	Electronic Brake Control Module																																																										
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2012	S10	Body	Body Control Module																																																										
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2012	S10	Body	Instrument Cluster																																																										
S	2012	S10	Body	Trailer Interface Control Module																																																										
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																										
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																												
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																												
S	2013	Colorado	Powertrain	Transfer Case Control Module																																																												
S	2013	Colorado	Chassis	Electronic Brake Control Module																																																												
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2013	Colorado	Body	Body Control Module																																																												
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2013	Colorado	Body	Instrument Cluster																																																												
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																												
S	2013	S10	Powertrain	Transfer Case Control Module																																																												
S	2013	S10	Chassis	Electronic Brake Control Module																																																												
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2013	S10	Body	Body Control Module																																																												
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2013	S10	Body	Instrument Cluster																																																												
S	2013	S10	Body	Trailer Interface Control Module																																																												
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																												
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																												
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																												
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																												
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2013	Trailblazer	Body	Body Control Module																																																												
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2013	Trailblazer	Body	Instrument Cluster																																																												
S	2013	Trailblazer	Body	Trailer Interface Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2013	Trailblazer	Body	Parking Assist Control Module																																																											
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																												
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																												
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																												
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2014	Colorado	Body	Body Control Module																																																												
S	2014	Colorado	Body	Body Control Module																																																												
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2014	Colorado	Body	Instrument Cluster																																																												
S	2014	Colorado	Body	Radio																																																											
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																												
S	2014	Colorado	Body	Parking Assist Control Module																																																												
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2014	S10	Powertrain	Transfer Case Control Module																																																												
S	2014	S10	Chassis	Electronic Brake Control Module																																																												
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2014	S10	Body	Body Control Module																																																												
S	2014	S10	Body	Body Control Module																																																												
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2014	S10	Body	Instrument Cluster																																																												
S	2014	S10	Body	Trailer Interface Control Module																																																												
S	2014	S10	Body	Radio																																																												
S	2014	S10	Body	Parking Assist Control Module																																																												
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																												
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																											
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2014	Trailblazer	Body	Body Control Module																																																												
S	2014	Trailblazer	Body	Body Control Module																																																												
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2014	Trailblazer	Body	Instrument Cluster																																																												
S	2014	Trailblazer	Body	Trailer Interface Control Module																																																												
S	2014	Trailblazer	Body	Parking Assist Control Module																																																												
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
S	2015	Colorado	Powertrain	Chassis Control Module																																																													
S	2015	Colorado	Powertrain	Transfer Case Control Module																													V																																
S	2015	Colorado	Chassis	Electronic Brake Control Module																																																												
S	2015	Colorado	Chassis	Power Steering Control Module																																																												
S	2015	Colorado	Body	Body Control Module																																																												
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2015	Colorado	Body	Passenger Presence Module																																																												
S	2015	Colorado	Body	Radio																																																											
S	2015	Colorado	Body	Amplifier																																																											
S	2015	Colorado	Body	Human Machine Interface Control Module																																																											
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																																											
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																											
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																											
S	2015	Colorado	Body	Frontview Camera Module																																																											
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																											
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																											
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																											
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2015	Colorado (MMM)	Body	Body Control Module																																																											
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2015	Colorado (MMM)	Body	Instrument Cluster																																																										
S	2015	Colorado (MMM)	Body	Radio																																																										
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																										
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																										
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	S10	Powertrain	Transfer Case Control Module																																																										
S	2015	S10	Chassis	Electronic Brake Control Module																																																										
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	S10	Body	Body Control Module																																																										
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	S10	Body	Instrument Cluster																																																										
S	2015	S10	Body	Trailer Interface Control Module																																																										
S	2015	S10	Body	Radio																																																										
S	2015	S10	Body	Telematics Communication Interface Control Module																																																										
S	2015	S10	Body	Parking Assist Control Module																																																										
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																										
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																										
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																										
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																										
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																										
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																										
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																										
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																										
S	2015	Trailblazer	Body	Body Control Module																																																										
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
S	2015	Trailblazer	Body	Instrument Cluster																																																										
S	2015	Trailblazer	Body	Trailer Interface Control Module																																																										
S	2015	Trailblazer	Body	Radio																																																										
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																										
S	2015	Trailblazer	Body	Parking Assist Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																													V																															
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																											
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																											
S	2016	Colorado (1GC)	Body	Body Control Module																																																											
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																																											
S	2016	Colorado (1GC)	Body	Radio Controls																																																											
S	2016	Colorado (1GC)	Body	HVAC Controls																																																											
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																											
S	2016	Colorado (1GC)	Body	Radio																																																											
S	2016	Colorado (1GC)	Body	Amplifier																																																											
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																											
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																											
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																											
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																											
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																											
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																																											
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																											
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																											
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																											
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																											
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2016	Colorado (MMM)	Body	Body Control Module																																																											
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2016	Colorado (MMM)	Body	Instrument Cluster																																																											
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																											
S	2016	Colorado (MMM)	Body	Radio																																																											
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																											
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																											
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																											
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																											
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																											
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																											
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																											
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
S	2016	S10	Powertrain	Transfer Case Control Module																																																											
S	2016	S10	Chassis	Electronic Brake Control Module																																																											
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
S	2016	S10	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
S	2016	S10	Body	Instrument Cluster																																																												
S	2016	S10	Body	Trailer Interface Control Module																																																												
S	2016	S10	Body	Radio																																																												
S	2016	S10	Body	Telematics Communication Interface Control Module																																																												
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																												
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																												
S	2016	S10	Body	Parking Assist Control Module																																																												
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																												
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																												
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2016	Trailblazer	Body	Body Control Module																																																												
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2016	Trailblazer	Body	Instrument Cluster																																																												
S	2016	Trailblazer	Body	Trailer Interface Control Module																																																												
S	2016	Trailblazer	Body	Radio																																																												
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																												
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																												
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																												
S	2016	Trailblazer	Body	Parking Assist Control Module																																																												
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2004	S10	Chassis	4WAL 3 Sensor																																																												
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																												
T	2004	S10	Body	Body Control Module																																																												
T	2004	S10	Body	Instrument Panel Cluster																																																												
T	2004	S10	Body	Base Radio																																																												
T	2004	S10	Body	Uplevel Radio																																																												
T	2004	S10	Body	Supplemental Inflatable Restraint		V																																																										
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2004	Colorado	Chassis	ABS Without Traction Control																																																												
T	2004	Colorado	Chassis	ABS With Traction Control																																																												
T	2004	Colorado	Body	Body Control Module																																																												
T	2004	Colorado	Body	Instrument Panel Cluster																																																												
T	2004	Colorado	Body	OnStar																																																											
T	2004	Colorado	Body	Base Radio																																																											
T	2004	Colorado	Body	Uplevel Radio																																																											
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																																											
T	2004	Colorado	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																											
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																											
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																											
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																											
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																											
T	2004	TrailBlazer	Body	Body Control Module																																																											
T	2004	TrailBlazer	Body	Driver Door Module																																																											
T	2004	TrailBlazer	Body	Driver Seat Module																																																											
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																											
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																											
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																																											
T	2004	TrailBlazer	Body	Lift Gate Module																																																											
T	2004	TrailBlazer	Body	OnStar																																																											
T	2004	TrailBlazer	Body	Passenger Door Module																																																											
T	2004	TrailBlazer	Body	Uplevel Radio																																																											
T	2004	TrailBlazer	Body	Navigation Radio																																																											
T	2004	TrailBlazer	Body	Rear Seat Audio																																																											
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																											
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint		V																																																									
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																											
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																											
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																											
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																											
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																											
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																											
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																											
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																											
T	2004	TrailBlazer EXT	Body	Body Control Module																																																											
T	2004	TrailBlazer EXT	Body	Driver Door Module																																																											
T	2004	TrailBlazer EXT	Body	Driver Seat Module																																																											
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																											
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																											
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																											
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																											
T	2004	TrailBlazer EXT	Body	OnStar																																																											
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																																											
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																											
T	2004	TrailBlazer EXT	Body	Navigation Radio																																																											
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																											
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																											
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																											
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint		V																																																									
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																											
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																												
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																											
T	2004	Blazer	Body	Body Control Module																																																											
T	2004	Blazer	Body	Heating and Air Conditioning																																																												
T	2004	Blazer	Body	Instrument Panel Cluster																																																												
T	2004	Blazer	Body	Memory Seat Module																																																												
T	2004	Blazer	Body	Base Radio																																																												
T	2004	Blazer	Body	Uplevel Radio																																																												
T	2004	Blazer	Body	Supplemental Inflatable Restraint		V																																																										
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2005	Colorado	Chassis	ABS Without Traction Control																																																												
T	2005	Colorado	Chassis	ABS With Traction Control																																																												
T	2005	Colorado	Body	Body Control Module																																																												
T	2005	Colorado	Body	Instrument Panel Cluster																																																												
T	2005	Colorado	Body	Base Radio																																																												
T	2005	Colorado	Body	Uplevel Radio																																																												
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																																												
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																																												
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																												
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																												
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																												
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																												
T	2005	TrailBlazer	Body	Body Control Module																																																												
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																												
T	2005	TrailBlazer	Body	Driver Door Module																																																												
T	2005	TrailBlazer	Body	Driver Seat Module																																																												
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																												
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																												
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																																												
T	2005	TrailBlazer	Body	Lift Gate Module																																																												
T	2005	TrailBlazer	Body	Passenger Door Module																																																												
T	2005	TrailBlazer	Body	Passenger Presence System																																																												
T	2005	TrailBlazer	Body	Uplevel Radio																																																												
T	2005	TrailBlazer	Body	Navigation Radio																																																												
T	2005	TrailBlazer	Body	Rear Seat Audio																																																												
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																												
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																												
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																											
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																											
T	2005	TrailBlazer EXT	Body	Body Control Module																																																											
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																											
T	2005	TrailBlazer EXT	Body	Driver Door Module																																																											
T	2005	TrailBlazer EXT	Body	Driver Seat Module																																																											
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																											
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																											
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																											
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																											
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																																											
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																											
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																											
T	2005	TrailBlazer EXT	Body	Navigation Radio																																																											
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																											
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																											
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																											
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																											
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																											
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																											
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																											
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																											
T	2005	Blazer	Body	Body Control Module																																																											
T	2005	Blazer	Body	Heating and Air Conditioning																																																											
T	2005	Blazer	Body	Instrument Panel Cluster																																																											
T	2005	Blazer	Body	Memory Seat Module																																																											
T	2005	Blazer	Body	Base Radio																																																											
T	2005	Blazer	Body	Uplevel Radio																																																											
T	2005	Blazer	Body	Supplemental Inflatable Restraint		V																																																									
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
T	2006	Colorado	Chassis	ABS Without Traction Control																																																											
T	2006	Colorado	Chassis	ABS With Traction Control																																																											
T	2006	Colorado	Body	Body Control Module																																																											
T	2006	Colorado	Body	Instrument Panel Cluster																																																											
T	2006	Colorado	Body	Passenger Presence System																																																											
T	2006	Colorado	Body	Base Radio																																																											
T	2006	Colorado	Body	Uplevel Radio																																																											
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																																											
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																																											
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																											
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																											
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																												
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																												
T	2006	TrailBlazer	Body	Body Control Module																																																												
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																												
T	2006	TrailBlazer	Body	Driver Door Module																																																												
T	2006	TrailBlazer	Body	Driver Seat Module																																																												
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																												
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																												
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																																												
T	2006	TrailBlazer	Body	Lift Gate Module																																																												
T	2006	TrailBlazer	Body	Passenger Door Module																																																												
T	2006	TrailBlazer	Body	Passenger Presence System																																																												
T	2006	TrailBlazer	Body	Uplevel Radio																																																												
T	2006	TrailBlazer	Body	Navigation Radio																																																												
T	2006	TrailBlazer	Body	Rear Seat Audio																																																												
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																												
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																												
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																												
T	2006	TrailBlazer EXT	Body	Body Control Module																																																												
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																												
T	2006	TrailBlazer EXT	Body	Driver Door Module																																																												
T	2006	TrailBlazer EXT	Body	Driver Seat Module																																																												
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																												
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																												
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																												
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																												
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																																												
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																												
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																												
T	2006	TrailBlazer EXT	Body	Navigation Radio																																																												
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																												
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																												
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																												
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																												
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																												
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																												
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																											
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																											
T	2007	Colorado	Body	Body Control Module																																																											
T	2007	Colorado	Body	Digital Radio Receiver																																																											
T	2007	Colorado	Body	Generator Battery Control Module																																																											
T	2007	Colorado	Body	Instrument Panel Cluster																																																											
T	2007	Colorado	Body	Passenger Presence System																																																											
T	2007	Colorado	Body	Base Radio																																																											
T	2007	Colorado	Body	Uplevel Radio																																																											
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																																											
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																																											
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																											
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																											
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																											
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																											
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																											
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																											
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																											
T	2007	Trailblazer	Body	Body Control Module																																																											
T	2007	Trailblazer	Body	Digital Radio Receiver																																																											
T	2007	Trailblazer	Body	Disc Player and Video Display																																																											
T	2007	Trailblazer	Body	Driver Door Module																																																											
T	2007	Trailblazer	Body	Driver Seat Module																																																											
T	2007	Trailblazer	Body	Generator Battery Control Module																																																											
T	2007	Trailblazer	Body	HVAC Control Module Auto																																																											
T	2007	Trailblazer	Body	HVAC Control Module Manual																																																											
T	2007	Trailblazer	Body	Instrument Panel Cluster																																																											
T	2007	Trailblazer	Body	Lift Gate Module																																																											
T	2007	Trailblazer	Body	Passenger Door Module																																																											
T	2007	Trailblazer	Body	Passenger Presence System																																																											
T	2007	Trailblazer	Body	Uplevel Radio																																																											
T	2007	Trailblazer	Body	Navigation Radio																																																											
T	2007	Trailblazer	Body	Rear Seat Audio																																																											
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																											
T	2007	Trailblazer	Body	Theft Deterrent Module																																																											
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																											
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																											
T	2008	Colorado	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2008	Colorado	Body	Digital Radio Receiver																																																								
T	2008	Colorado	Body	Generator Battery Control Module																																																								
T	2008	Colorado	Body	Instrument Panel Cluster																																																								
T	2008	Colorado	Body	Passenger Presence System																																																								
T	2008	Colorado	Body	Base Radio																																																								
T	2008	Colorado	Body	Uplevel Radio																																																								
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																																								
T	2008	Colorado	Body	Theft Deterrent Module																																																								
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																																								
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																								
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																								
T	2008	TrailBlazer	Body	Body Control Module																																																								
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																								
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																								
T	2008	TrailBlazer	Body	Driver Door Module																																																								
T	2008	TrailBlazer	Body	Driver Seat Module																																																								
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																								
T	2008	TrailBlazer	Body	HVAC Control Module Auto																																																								
T	2008	TrailBlazer	Body	HVAC Control Module Manual																																																								
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																																								
T	2008	TrailBlazer	Body	Lift Gate Module																																																								
T	2008	TrailBlazer	Body	Passenger Door Module																																																								
T	2008	TrailBlazer	Body	Passenger Presence System																																																								
T	2008	TrailBlazer	Body	Uplevel Radio																																																								
T	2008	TrailBlazer	Body	Navigation Radio																																																								
T	2008	TrailBlazer	Body	Rear Seat Audio																																																								
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																								
T	2008	TrailBlazer	Body	Theft Deterrent Module																																																								
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																								
T	2009	Colorado	Chassis	Electronic Brake Control Module																																																								
T	2009	Colorado	Body	Body Control Module																																																								
T	2009	Colorado	Body	Digital Radio Receiver																																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2009	Colorado	Body	Generator Battery Control Module																																																												
T	2009	Colorado	Body	Instrument Panel Cluster																																																												
T	2009	Colorado	Body	Passenger Presence System																																																												
T	2009	Colorado	Body	Base Radio																																																												
T	2009	Colorado	Body	Uplevel Radio																																																												
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																																												
T	2009	Colorado	Body	Theft Deterrent Module																																																												
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																												
T	2009	TrailBlazer	Body	Body Control Module																																																												
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																												
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																												
T	2009	TrailBlazer	Body	Driver Door Module																																																												
T	2009	TrailBlazer	Body	Driver Seat Module																																																												
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																												
T	2009	TrailBlazer	Body	HVAC Control Module Auto																																																												
T	2009	TrailBlazer	Body	HVAC Control Module Manual																																																												
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																																												
T	2009	TrailBlazer	Body	Lift Gate Module																																																												
T	2009	TrailBlazer	Body	Passenger Door Module																																																												
T	2009	TrailBlazer	Body	Passenger Presence System																																																												
T	2009	TrailBlazer	Body	Uplevel Radio																																																												
T	2009	TrailBlazer	Body	Navigation Radio																																																												
T	2009	TrailBlazer	Body	Rear Seat Audio																																																												
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
T	2009	TrailBlazer	Body	Theft Deterrent Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																												
T	2010	ALL	Chassis	Electronic Brake Control Module																																																												
T	2010	ALL	Body	Body Control Module																																																											
T	2010	ALL	Body	Digital Radio Receiver																																																												
T	2010	ALL	Body	Generator Battery Control Module																																																												
T	2010	ALL	Body	Instrument Panel Cluster																																																												
T	2010	ALL	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2010	ALL	Body	Personal Audio Link Module																																																											
T	2010	ALL	Body	Base Radio																																																											
T	2010	ALL	Body	Uplevel Radio																																																											
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2010	ALL	Body	Theft Deterrent Module																																																											
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																											
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
T	2011	ALL	Chassis	Electronic Brake Control Module																																																											
T	2011	ALL	Body	Body Control Module																																																										
T	2011	ALL	Body	Digital Radio Receiver																																																										
T	2011	ALL	Body	Generator Battery Control Module																																																										
T	2011	ALL	Body	Instrument Panel Cluster																																																										
T	2011	ALL	Body	Passenger Presence System																																																										
T	2011	ALL	Body	Personal Audio Link Module																																																										
T	2011	ALL	Body	Base Radio																																																										
T	2011	ALL	Body	Uplevel Radio																																																										
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2011	ALL	Body	Theft Deterrent Module																																																										
T	2011	ALL	Body	Vehicle Comm. Interface Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																										
T	2012	Colorado (First Gen)	Body	Body Control Module																																																										
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																										
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																										
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																										
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																										
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																										
T	2012	Colorado (First Gen)	Body	Base Radio																																																										
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																								
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																								
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																								
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																								
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2012	Colorado (Second Gen)	Body	Body Control Module																																																								
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																								
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																								
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2012	S10	Powertrain	Transfer Case Control Module																																																								
T	2012	S10	Chassis	Electronic Brake Control Module																																																								
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																								
T	2012	S10	Body	Body Control Module																																																								
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
T	2012	S10	Body	Instrument Cluster																																																								
T	2012	S10	Body	Trailer Interface Control Module																																																								
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																								
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																								
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																								
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																								
T	2013	Colorado	Powertrain	Transfer Case Control Module																																																								
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																								
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																								
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2013	Colorado	Body	Body Control Module																																																											
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	Colorado	Body	Instrument Cluster																																																											
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																											
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																											
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																											
T	2013	S10	Powertrain	Transfer Case Control Module																																																											
T	2013	S10	Chassis	Electronic Brake Control Module																																																											
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2013	S10	Body	Body Control Module																																																											
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	S10	Body	Instrument Cluster																																																											
T	2013	S10	Body	Trailer Interface Control Module																																																											
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																											
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																											
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																											
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																											
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																											
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																											
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																											
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																											
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2013	Trailblazer	Body	Body Control Module																																																											
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2013	Trailblazer	Body	Instrument Cluster																																																											
T	2013	Trailblazer	Body	Trailer Interface Control Module																																																											
T	2013	Trailblazer	Body	Parking Assist Control Module																																																											
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																											
T	2014	Colorado	Powertrain	Transfer Case Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																											
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2014	Colorado	Body	Body Control Module																																																											
T	2014	Colorado	Body	Body Control Module																																																											
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2014	Colorado	Body	Instrument Cluster																																																											
T	2014	Colorado	Body	Radio																																																											
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																											
T	2014	Colorado	Body	Parking Assist Control Module																																																											
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																											
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																											
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																											
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																											
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2014	S10	Powertrain	Transfer Case Control Module																																																											
T	2014	S10	Chassis	Electronic Brake Control Module																																																											
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2014	S10	Body	Body Control Module																																																										
T	2014	S10	Body	Body Control Module																																																										
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2014	S10	Body	Instrument Cluster																																																										
T	2014	S10	Body	Trailer Interface Control Module																																																										
T	2014	S10	Body	Radio																																																										
T	2014	S10	Body	Parking Assist Control Module																																																										
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																											
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																											
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																											
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																											
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																											
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2014	Trailblazer	Body	Body Control Module																																																										
T	2014	Trailblazer	Body	Body Control Module																																																										
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2014	Trailblazer	Body	Instrument Cluster																																																										
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																										
T	2014	Trailblazer	Body	Parking Assist Control Module																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																												
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2015	Colorado	Powertrain	Chassis Control Module																																																												
T	2015	Colorado	Powertrain	Transfer Case Control Module																													V																															
T	2015	Colorado	Chassis	Electronic Brake Control Module																																																												
T	2015	Colorado	Chassis	Power Steering Control Module																																																												
T	2015	Colorado	Body	Body Control Module																																																												
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2015	Colorado	Body	Passenger Presence Module																																																												
T	2015	Colorado	Body	Radio																																																												
T	2015	Colorado	Body	Amplifier																																																												
T	2015	Colorado	Body	Human Machine Interface Control Module																																																												
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																																												
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																												
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																												
T	2015	Colorado	Body	Frontview Camera Module																																																												
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																												
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																												
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																												
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2015	Colorado (MMM)	Body	Body Control Module																																																												
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2015	Colorado (MMM)	Body	Instrument Cluster																																																												
T	2015	Colorado (MMM)	Body	Radio																																																												
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																												
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																												
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																												
T	2015	S10	Powertrain	Transfer Case Control Module																																																												
T	2015	S10	Chassis	Electronic Brake Control Module																																																												
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2015	S10	Body	Body Control Module																																																												
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2015	S10	Body	Instrument Cluster																																																												
T	2015	S10	Body	Trailer Interface Control Module																																																												
T	2015	S10	Body	Radio																																																												
T	2015	S10	Body	Telematics Communication Interface Control Module																																																												
T	2015	S10	Body	Parking Assist Control Module																																																												
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																												
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																												
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																												
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2015	Trailblazer	Body	Body Control Module																																																												
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2015	Trailblazer	Body	Instrument Cluster																																																												
T	2015	Trailblazer	Body	Trailer Interface Control Module																																																												
T	2015	Trailblazer	Body	Radio																																																												
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																												
T	2015	Trailblazer	Body	Parking Assist Control Module																																																												
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																												
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																													V																															
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																												
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																												
T	2016	Colorado (1GC)	Body	Body Control Module																																																												
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																																												
T	2016	Colorado (1GC)	Body	Radio Controls																																																												
T	2016	Colorado (1GC)	Body	HVAC Controls																																																												
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																												
T	2016	Colorado (1GC)	Body	Radio																																																												
T	2016	Colorado (1GC)	Body	Amplifier																																																												
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																											
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																											
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																											
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																											
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																											
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																											
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																											
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																											
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2016	Colorado (MMM)	Body	Body Control Module																																																											
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																											
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																											
T	2016	Colorado (MMM)	Body	Radio																																																											
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																											
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																											
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																											
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																											
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																											
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																											
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
T	2016	S10	Powertrain	Transfer Case Control Module																																																											
T	2016	S10	Chassis	Electronic Brake Control Module																																																											
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2016	S10	Body	Body Control Module																																																										
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2016	S10	Body	Instrument Cluster																																																											
T	2016	S10	Body	Trailer Interface Control Module																																																											
T	2016	S10	Body	Radio																																																										
T	2016	S10	Body	Telematics Communication Interface Control Module																																																											
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																											
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																											
T	2016	S10	Body	Parking Assist Control Module																																																											
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																											
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																											
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2016	Trailblazer	Body	Body Control Module																																																											
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2016	Trailblazer	Body	Instrument Cluster																																																											
T	2016	Trailblazer	Body	Trailer Interface Control Module																																																											
T	2016	Trailblazer	Body	Radio																																																											
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																											
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																											
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																											
T	2016	Trailblazer	Body	Parking Assist Control Module																																																											
V	2009	ALL	Powertrain	Engine Control Module																																																											
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2009	ALL	Powertrain	Rear Drive System																																																											
V	2009	ALL	Powertrain	Transmission Control Module																																																											
V	2009	ALL	Chassis	Electronic Brake Control Module					V																																																						
V	2009	ALL	Body	Body Control Module																																																											
V	2009	ALL	Body	Digital Radio Receiver																																																											
V	2009	ALL	Body	Driver Door Switch																																																											
V	2009	ALL	Body	Heated Seat Module																																																											
V	2009	ALL	Body	HVAC Control Module Auto						V																																																					
V	2009	ALL	Body	HVAC Control Module Manual						V																																																					
V	2009	ALL	Body	Instrument Panel Cluster																																																											
V	2009	ALL	Body	Lift Gate Module																																																											
V	2009	ALL	Body	Park Assist Module								V																																																		
V	2009	ALL	Body	Passenger Door Switch																																																											
V	2009	ALL	Body	Passenger Presence System																																																											
V	2009	ALL	Body	Radio																																																											
V	2009	ALL	Body	Rear HVAC/RSA																																																											
V	2009	ALL	Body	Rollover Sensor																																																											
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2009	ALL	Body	Theft Deterrent Module																																																											
V	2010	ALL	Powertrain	Engine Control Module																																																											
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2010	ALL	Powertrain	Rear Drive System																																																											
V	2010	ALL	Powertrain	Transmission Control Module																																																											
V	2010	ALL	Chassis	Electronic Brake Control Module					V																																																						
V	2010	ALL	Body	Body Control Module																																																											
V	2010	ALL	Body	Digital Radio Receiver																																																											
V	2010	ALL	Body	Driver Door Switch																																																											
V	2010	ALL	Body	Heated Seat Module																																																											
V	2010	ALL	Body	HVAC Control Module Auto						V																																																					
V	2010	ALL	Body	HVAC Control Module Manual						V																																																					
V	2010	ALL	Body	Instrument Panel Cluster																																																											
V	2010	ALL	Body	Lift Gate Module																																																											
V	2010	ALL	Body	Park Assist Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
V	2010	ALL	Body	Passenger Door Switch																																																												
V	2010	ALL	Body	Passenger Presence System																																																												
V	2010	ALL	Body	Radio																																																												
V	2010	ALL	Body	Rear HVAC/RSA																																																												
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2010	ALL	Body	Theft Deterrent Module																																																												
V	2011	ALL	Powertrain	Engine Control Module																																																												
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2011	ALL	Powertrain	Rear Drive System																																																												
V	2011	ALL	Powertrain	Transmission Control Module																																																												
V	2011	ALL	Chassis	Electronic Brake Control Module					V																																																							
V	2011	ALL	Body	Body Control Module																																																												
V	2011	ALL	Body	Digital Radio Receiver																																																												
V	2011	ALL	Body	Driver Door Switch																																																												
V	2011	ALL	Body	Heated Seat Module																																																												
V	2011	ALL	Body	HVAC Control Module Auto						V																																										V											
V	2011	ALL	Body	HVAC Control Module Manual						V																																																					
V	2011	ALL	Body	Instrument Panel Cluster																																																												
V	2011	ALL	Body	Lift Gate Module																																																												
V	2011	ALL	Body	Park Assist Module																																																												
V	2011	ALL	Body	Passenger Door Switch																																																												
V	2011	ALL	Body	Passenger Presence System																																																												
V	2011	ALL	Body	Radio																																																												
V	2011	ALL	Body	Rear HVAC/RSA																																																												
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2011	ALL	Body	Theft Deterrent Module																																																												
V	2012	ALL	Powertrain	Engine Control Module																																																												
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2012	ALL	Powertrain	Rear Drive System																																																												
V	2012	ALL	Powertrain	Transmission Control Module																																																												
V	2012	ALL	Chassis	Electronic Brake Control Module					V																																																							
V	2012	ALL	Body	Body Control Module																																																												
V	2012	ALL	Body	Digital Radio Receiver																																																												
V	2012	ALL	Body	Driver Door Switch																																																												
V	2012	ALL	Body	Heated Seat Module																																																												
V	2012	ALL	Body	HVAC Control Module Auto						V																																										V											
V	2012	ALL	Body	HVAC Control Module Manual						V																																																					
V	2012	ALL	Body	Instrument Panel Cluster																																																												
V	2012	ALL	Body	Lift Gate Module																																																												
V	2012	ALL	Body	Park Assist Module																																																												
V	2012	ALL	Body	Passenger Door Switch																																																												
V	2012	ALL	Body	Passenger Presence System																																																												
V	2012	ALL	Body	Radio																																																												
V	2012	ALL	Body	Rear HVAC/RSA																																																												
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2012	ALL	Body	Theft Deterrent Module																																																												
V	2013	ALL	Powertrain	Engine Control Module																																																												
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2013	ALL	Powertrain	Rear Drive System																																																												
V	2013	ALL	Powertrain	Transmission Control Module																																																												
V	2013	ALL	Chassis	Electronic Brake Control Module					V																																																							

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
V	2013	ALL	Body	Body Control Module																																																										
V	2013	ALL	Body	Digital Radio Receiver																																																										
V	2013	ALL	Body	Driver Door Switch																																																										
V	2013	ALL	Body	Heated Seat Module																																																										
V	2013	ALL	Body	HVAC Control Module Auto						V																																								V												
V	2013	ALL	Body	HVAC Control Module Manual						V																																																				
V	2013	ALL	Body	Instrument Panel Cluster																																																										
V	2013	ALL	Body	Left Side Object Detection Module																																																										
V	2013	ALL	Body	Lift Gate Module																																																										
V	2013	ALL	Body	Park Assist Module																																																										
V	2013	ALL	Body	Passenger Door Switch																																																										
V	2013	ALL	Body	Passenger Presence System																																																										
V	2013	ALL	Body	Radio																																																										
V	2013	ALL	Body	Rear HVAC/RSA																																																										
V	2013	ALL	Body	Right Side Object Detection Module																																																										
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2013	ALL	Body	Theft Deterrent Module																																																										
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2014	Traverse	Powertrain	Chassis Control Module																																																										
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2014	Traverse	Chassis	Electronic Brake Control Module																																																										
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2014	Traverse	Body	Passenger Presence Module																																																										
V	2014	Traverse	Body	Instrument Cluster																																																										
V	2014	Traverse	Body	Radio																																																										
V	2014	Traverse	Body	Rear Audio Control Module																																																										
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2014	Traverse	Body	Personal Audio Link Control Module																																																										
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																										
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
V	2014	Traverse	Body	Liftgate Control Module																																																										
V	2014	Traverse	Body	Seat Memory Control Module																																																										
V	2014	Traverse	Body	Front Seat Heating Control Module																																																										
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2014	Traverse	Body	Parking Assist Control Module																																																										
V	2014	Traverse	Body	Frontview Camera Module																																																										
V	2014	Traverse	Body	Theft Deterrent Module																																																										
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2015	Traverse	Chassis	Electronic Brake Control Module																																																										
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																											
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
V	2015	Traverse	Body	Passenger Presence Module																																																											
V	2015	Traverse	Body	Instrument Cluster																																																										
V	2015	Traverse	Body	Radio																																																										
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2015	Traverse	Body	Liftgate Control Module																																																										
V	2015	Traverse	Body	Seat Memory Control Module																																																										
V	2015	Traverse	Body	Front Seat Heating Control Module																																																										
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2015	Traverse	Body	Parking Assist Control Module																																																										
V	2015	Traverse	Body	Frontview Camera Module																																																										
V	2015	Traverse	Body	Theft Deterrent Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Traverse	Chassis	Electronic Brake Control Module																																																										
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																										
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Traverse	Body	Passenger Presence Module																																																										
V	2016	Traverse	Body	Instrument Cluster																																																										
V	2016	Traverse	Body	Radio																																																										
V	2016	Traverse	Body	Rear Audio Control Module																																																										
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																										
V	2016	Traverse	Body	Personal Audio Link Control Module																																																										
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																										
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Traverse	Body	Liftgate Control Module																																																										
V	2016	Traverse	Body	Seat Memory Control Module																																																										
V	2016	Traverse	Body	Front Seat Heating Control Module																																																										
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																										
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																										
V	2016	Traverse	Body	Parking Assist Control Module																																																										
V	2016	Traverse	Body	Frontview Camera Module																																																										
V	2016	Traverse	Body	Theft Deterrent Module																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																												
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																												
A	2011	Orlando	Chassis	Parking Brake Control Module																																																												
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2011	Orlando	Chassis	Power Steering Control Module																																																												
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2011	Orlando	Body	Body Control Module																																																												
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2011	Orlando	Body	Instrument Cluster																																																												
A	2011	Orlando	Body	Trailer Interface Control Module																																																												
A	2011	Orlando	Body	Radio																																																												
A	2011	Orlando	Body	Multimedia Player Interface Module																																																												
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																												
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																												
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																												
A	2011	Orlando	Body	Keyless Entry Control Module																																																												
A	2011	Orlando	Body	Parking Assist Control Module																																																												
A	2011	Orlando	Body	Steering Column Lock Control Module																																																												
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																												
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																												
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																												
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																												
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																												
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																												
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																												
A	2012	Orlando	Chassis	Parking Brake Control Module																																																												
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2012	Orlando	Chassis	Power Steering Control Module																																																												
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2012	Orlando	Body	Body Control Module																																																												
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2012	Orlando	Body	Instrument Cluster																																																												
A	2012	Orlando	Body	Trailer Interface Control Module																																																												
A	2012	Orlando	Body	Radio																																																												
A	2012	Orlando	Body	Multimedia Player Interface Module																																																												
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																												
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																												
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																												
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																												
A	2012	Orlando	Body	Keyless Entry Control Module																																																												
A	2012	Orlando	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
A	2012	Orlando	Body	Steering Column Lock Control Module																																																										
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																										
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																										
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																										
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																										
A	2013	Orlando	Chassis	Parking Brake Control Module																																																										
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
A	2013	Orlando	Chassis	Power Steering Control Module																																																										
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
A	2013	Orlando	Body	Body Control Module																																																										
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
A	2013	Orlando	Body	Instrument Cluster																																																										
A	2013	Orlando	Body	Radio																																																										
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																										
A	2013	Orlando	Body	Multimedia Player Interface Module																																																										
A	2013	Orlando	Body	Mobile Telephone Control Module																																																										
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																										
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																										
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
A	2013	Orlando	Body	Front Seat Heating Control Module																																																										
A	2013	Orlando	Body	Keyless Entry Control Module																																																										
A	2013	Orlando	Body	Parking Assist Control Module																																																										
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																										
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																									
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																									
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2014	Orlando	Chassis	Power Steering Control Module																																																									
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2014	Orlando	Body	Body Control Module																																																									
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2014	Orlando	Body	Instrument Cluster																																																									
A	2014	Orlando	Body	Radio																																																									
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																									
A	2014	Orlando	Body	Multimedia Player Interface Module																																																									
A	2014	Orlando	Body	Mobile Telephone Control Module																																																									
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																									
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																									
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																									
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																									
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																									
A	2014	Orlando	Body	Front Seat Heating Control Module																																																									
A	2014	Orlando	Body	Rear Seat Heating Control Module																																																									
A	2014	Orlando	Body	Keyless Entry Control Module																																																									
A	2014	Orlando	Body	Parking Assist Control Module																																																									
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																									
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																									
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																									
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																									
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																									
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																									
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																									
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																									
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																									
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																									
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																									
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																									
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																									
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																									
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																									
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																									
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																									
A	2015	Orlando	Chassis	Power Steering Control Module																																																									
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																									
A	2015	Orlando	Body	Body Control Module																																																								
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
A	2015	Orlando	Body	Instrument Cluster																																																									
A	2015	Orlando	Body	Radio																																																									
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																									
A	2015	Orlando	Body	Mobile Telephone Control Module																																																									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																											
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																											
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																											
A	2015	Orlando	Body	Front Seat Heating Control Module																																																											
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																											
A	2015	Orlando	Body	Keyless Entry Control Module																																																											
A	2015	Orlando	Body	Parking Assist Control Module																																																											
A	2015	Orlando	Body	Frontview Camera Module																																																											
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																											
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																											
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																											
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																											
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																											
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																											
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																											
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																											
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																											
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2016	Orlando	Chassis	Power Steering Control Module																																																											
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2016	Orlando	Body	Body Control Module																																																											
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2016	Orlando	Body	Instrument Cluster																																																											
A	2016	Orlando	Body	Radio																																																											
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																											
A	2016	Orlando	Body	Multimedia Player Interface Module																																																											
A	2016	Orlando	Body	Mobile Telephone Control Module																																																											
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																											
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																											
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																											
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																											
A	2016	Orlando	Body	Front Seat Heating Control Module																																																											
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																											
A	2016	Orlando	Body	Keyless Entry Control Module																																																											
A	2016	Orlando	Body	Parking Assist Control Module																																																											
A	2016	Orlando	Body	Frontview Camera Module																																																											
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																																																											
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																																																											
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																																																											
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																																																												
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																																																												
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2009	N200	Chassis	Electronic Brake Control Module																																																												
C	2009	N200	Body	Supplemental Inflatable Restraint																																																												
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2009	N300	Chassis	Electronic Brake Control Module																																																												
C	2009	N300	Body	Supplemental Inflatable Restraint																																																												
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2010	N200	Chassis	Electronic Brake Control Module																																																												
C	2010	N200	Body	Supplemental Inflatable Restraint																																																												
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2010	N300	Chassis	Electronic Brake Control Module																																																												
C	2010	N300	Body	Supplemental Inflatable Restraint																																																												
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2011	N200	Chassis	Electronic Brake Control Module																																																												
C	2011	N200	Body	Supplemental Inflatable Restraint																																																												
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2011	N300	Chassis	Electronic Brake Control Module																																																												
C	2011	N300	Body	Supplemental Inflatable Restraint																																																												
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2012	N200	Chassis	Electronic Brake Control Module																																																												
C	2012	N200	Body	Supplemental Inflatable Restraint																																																												
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																												
C	2012	N300	Chassis	Electronic Brake Control Module																																																												
C	2012	N300	Body	Supplemental Inflatable Restraint																																																												
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2013	N300	Chassis	Electronic Brake Control Module																																																												
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																																												
C	2014	N300	Chassis	Electronic Brake Control Module																																																												
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																																												
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																																												
C	2015	Max	Chassis	Electronic Brake Control Module																																																												
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																																												
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																																												
C	2015	Move	Chassis	Electronic Brake Control Module																																																												
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																																												
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																																												
C	2015	N300	Chassis	Electronic Brake Control Module																																																												
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																																												
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																																												
C	2016	Max	Chassis	Electronic Brake Control Module																																																												
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																																												
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																																												
C	2016	Move	Chassis	Electronic Brake Control Module																																																												
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module																																																												
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																																												
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																																												
C	2016	N300	Chassis	Electronic Brake Control Module																																																												
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																												
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																												
M	2015	City Express	Chassis	Electronic Brake Control Module																																																												
M	2015	City Express	Chassis	Power Steering Control Module																																																												
M	2015	City Express	Body	Body Control Module																																																											
M	2015	City Express	Body	Underhood Fuse Block																																																											
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2015	City Express	Body	Instrument Cluster																																																											
M	2015	City Express	Body	Tire Pressure Indicator Module																																																											
M	2015	City Express	Body	Radio																																																											
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																											
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																											
M	2016	City Express	Chassis	Electronic Brake Control Module																																																											
M	2016	City Express	Chassis	Power Steering Control Module																																																											
M	2016	City Express	Body	Body Control Module																																																										
M	2016	City Express	Body	Underhood Fuse Block																																																										
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
M	2016	City Express	Body	Instrument Cluster																																																										
M	2016	City Express	Body	Tire Pressure Indicator Module																																																										
M	2016	City Express	Body	Radio																																																										
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2011	Orlando	Chassis	Parking Brake Control Module																																																											
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2011	Orlando	Chassis	Power Steering Control Module																																																											
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
P	2011	Orlando	Body	Body Control Module																																																											
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2011	Orlando	Body	Instrument Cluster																																																											
P	2011	Orlando	Body	Trailer Interface Control Module																																																											
P	2011	Orlando	Body	Radio																																																											
P	2011	Orlando	Body	Multimedia Player Interface Module																																																											
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2011	Orlando	Body	Keyless Entry Control Module																																																											
P	2011	Orlando	Body	Parking Assist Control Module																																																											
P	2011	Orlando	Body	Steering Column Lock Control Module																																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																											
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																											
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																											
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																											
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																																											
P	2012	Orlando	Chassis	Electronic Brake Control Module																																																											
P	2012	Orlando	Chassis	Parking Brake Control Module																																																											
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																											
P	2012	Orlando	Chassis	Power Steering Control Module																																																											
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																											
P	2012	Orlando	Body	Body Control Module																																																											
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
P	2012	Orlando	Body	Instrument Cluster																																																											
P	2012	Orlando	Body	Trailer Interface Control Module																																																											
P	2012	Orlando	Body	Radio																																																											
P	2012	Orlando	Body	Multimedia Player Interface Module																																																											
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																											
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																											
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																											
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																											
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																											
P	2012	Orlando	Body	Keyless Entry Control Module																																																											
P	2012	Orlando	Body	Parking Assist Control Module																																																											
P	2012	Orlando	Body	Steering Column Lock Control Module																																																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																											
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																											
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																												
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																												
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																												
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																												
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																												
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																												
P	2013	Orlando	Chassis	Parking Brake Control Module																																																												
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2013	Orlando	Chassis	Power Steering Control Module																																																												
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2013	Orlando	Body	Body Control Module																																																												
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2013	Orlando	Body	Instrument Cluster																																																												
P	2013	Orlando	Body	Radio																																																											
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																												
P	2013	Orlando	Body	Multimedia Player Interface Module																																																												
P	2013	Orlando	Body	Mobile Telephone Control Module																																																												
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																												
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																												
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																												
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																												
P	2013	Orlando	Body	Front Seat Heating Control Module																																																												
P	2013	Orlando	Body	Keyless Entry Control Module																																																												
P	2013	Orlando	Body	Parking Assist Control Module																																																												
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																												
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																												
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																												
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																												
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
P	2014	Orlando	Chassis	Power Steering Control Module																																																												
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2014	Orlando	Body	Body Control Module																																																												
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2014	Orlando	Body	Instrument Cluster																																																												
P	2014	Orlando	Body	Radio																																																												
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																												
P	2014	Orlando	Body	Multimedia Player Interface Module																																																												
P	2014	Orlando	Body	Mobile Telephone Control Module																																																												
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																												
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																												
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																												
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																												
P	2014	Orlando	Body	Front Seat Heating Control Module																																																												
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																												
P	2014	Orlando	Body	Keyless Entry Control Module																																																												
P	2014	Orlando	Body	Parking Assist Control Module																																																												
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																												
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																												
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																												
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																												
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																												
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2015	Orlando	Chassis	Power Steering Control Module																																																												
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
P	2015	Orlando	Body	Body Control Module																																																												
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
P	2015	Orlando	Body	Instrument Cluster																																																												
P	2015	Orlando	Body	Radio																																																												
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																												
P	2015	Orlando	Body	Mobile Telephone Control Module																																																												
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																												
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																												
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																												
P	2015	Orlando	Body	Front Seat Heating Control Module																																																												
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																												
P	2015	Orlando	Body	Keyless Entry Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
P	2015	Orlando	Body	Parking Assist Control Module																																																										
P	2015	Orlando	Body	Frontview Camera Module																																																										
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																										
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																										
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																										
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																										
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																										
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																										
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																										
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																										
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																										
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																										
P	2016	Orlando	Chassis	Power Steering Control Module																																																										
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																										
P	2016	Orlando	Body	Body Control Module																																																										
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
P	2016	Orlando	Body	Instrument Cluster																																																										
P	2016	Orlando	Body	Radio																																																										
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																										
P	2016	Orlando	Body	Multimedia Player Interface Module																																																										
P	2016	Orlando	Body	Mobile Telephone Control Module																																																										
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																																										
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																										
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																										
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																										
P	2016	Orlando	Body	Front Seat Heating Control Module																																																										
P	2016	Orlando	Body	Rear Seat Heating Control Module																																																										
P	2016	Orlando	Body	Keyless Entry Control Module																																																										
P	2016	Orlando	Body	Parking Assist Control Module																																																										
P	2016	Orlando	Body	Frontview Camera Module																																																										
U	2004	ALL	Powertrain	Engine Control Module																																																										
U	2004	ALL	Powertrain	Transmission Control Module																																																										
U	2004	ALL	Body	Digital Radio Receiver																																																										
U	2004	ALL	Body	Driver Information Center																																																										
U	2004	ALL	Body	Instrument Panel Cluster																																																										
U	2004	ALL	Body	Radio																																																										
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2004	ALL	Body	Vehicle Theft Deterrent																																																										
U	2005	ALL	Powertrain	Engine Control Module																																																										
U	2005	ALL	Powertrain	Transmission Control Module																																																										
U	2005	ALL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
U	2005	ALL	Body	Body Control Module																																																										
U	2005	ALL	Body	Disc Player and Video																																																										
U	2005	ALL	Body	Digital Radio Receiver																																																										
U	2005	ALL	Body	HVAC Control Module																																																										
U	2005	ALL	Body	Instrument Panel Cluster																																																										
U	2005	ALL	Body	Left Power Sliding Door Module																																																										
U	2005	ALL	Body	Mobile Digital Media																																																										
U	2005	ALL	Body	Navigation Radio																																																										
U	2005	ALL	Body	Navigation Radio																																																										
U	2005	ALL	Body	Radio																																																										
U	2005	ALL	Body	Right Power Sliding Door Module																																																										
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																										
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																										
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																										
U	2006	ALL	Chassis	Electronic Brake Control Module																																																										
U	2006	ALL	Body	Body Control Module																																																										
U	2006	ALL	Body	Disc Player and Video																																																										
U	2006	ALL	Body	Digital Radio Receiver																																																										
U	2006	ALL	Body	HVAC Control Module																																																										
U	2006	ALL	Body	Instrument Panel Cluster																																																										
U	2006	ALL	Body	Left Power Sliding Door Module																																																										
U	2006	ALL	Body	Mobile Digital Media																																																										
U	2006	ALL	Body	Navigation Radio																																																										
U	2006	ALL	Body	Navigation Radio																																																										
U	2006	ALL	Body	Radio																																																										
U	2006	ALL	Body	Right Power Sliding Door Module																																																										
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																										
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
U	2007	ALL	Chassis	Electronic Brake Control Module																																																										
U	2007	ALL	Body	Body Control Module																																																										
U	2007	ALL	Body	Digital Radio Receiver																																																										
U	2007	ALL	Body	Disc Player and Video Display																																																										
U	2007	ALL	Body	HVAC Control Module																																																										
U	2007	ALL	Body	Left Power Sliding Door Module																																																										
U	2007	ALL	Body	Mobile Digital Media																																																										
U	2007	ALL	Body	Radio																																																										
U	2007	ALL	Body	Navigation Radio																																																										
U	2007	ALL	Body	Right Power Sliding Door Module																																																										
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																										
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
U	2008	ALL	Chassis	Electronic Brake Control Module																																																										
U	2008	ALL	Body	Body Control Module																																																										
U	2008	ALL	Body	Digital Radio Receiver																																																										
U	2008	ALL	Body	Disc Player and Video Display																																																										
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																												
U	2008	ALL	Body	Left Power Sliding Door Module																																																												
U	2008	ALL	Body	Radio																																																												
U	2008	ALL	Body	Navigation Radio																																																												
U	2008	ALL	Body	Remote Control Door Lock Receiver																																																												
U	2008	ALL	Body	Right Power Sliding Door Module																																																												
U	2009	ALL	Powertrain	Engine Control Module																																																													
U	2009	ALL	Powertrain	Transmission Control Module																																																													
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																													
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																													
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																													
U	2009	ALL	Body	Body Control Module																																																													
U	2009	ALL	Body	Digital Radio Receiver																																																													
U	2009	ALL	Body	Disc Player and Video Display																																																													
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																																													
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																													
U	2009	ALL	Body	Instrument Panel Cluster																																																													
U	2009	ALL	Body	Left Power Sliding Door Module																																																													
U	2009	ALL	Body	Radio																																																												
U	2009	ALL	Body	Remote Control Door Lock Receiver																																																													
U	2009	ALL	Body	Right Power Sliding Door Module																																																													
V	2004	ALL	Powertrain	Engine Data Display																																																													
V	2004	ALL	Powertrain	Transmission Data Display																																																													
V	2004	ALL	Body	Digital Radio Receiver																																																													
V	2004	ALL	Body	Driver Information Center																																																													
V	2004	ALL	Body	Instrument Panel Cluster																																																													
V	2004	ALL	Body	Radio																																																												
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2004	ALL	Body	Vehicle Theft Deterrent																																																												
V	2005	Venture	Powertrain	Engine Control Module																																																													
V	2005	Venture	Powertrain	Transmission Control Module																																																													
V	2005	Venture	Body	Digital Radio Receiver																																																													
V	2005	Venture	Body	Driver Information Center																																																													
V	2005	Venture	Body	Instrument Panel Cluster																																																													
V	2005	Venture	Body	Radio																																																												
V	2005	Venture	Body	Supplemental Inflatable Restraint																																																												
V	2005	Venture	Body	Vehicle Theft Deterrent																																																												
V	2005	Uplander	Powertrain	Engine Control Module																																																													
V	2005	Uplander	Powertrain	Transmission Control Module																																																													
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																													
V	2005	Uplander	Body	Body Control Module																																																													
V	2005	Uplander	Body	Disc Player and Video																																																													
V	2005	Uplander	Body	Digital Radio Receiver																																																													
V	2005	Uplander	Body	HVAC Control Module																																																													
V	2005	Uplander	Body	Instrument Panel Cluster																																																													
V	2005	Uplander	Body	Left Power Sliding Door Module																																																													
V	2005	Uplander	Body	Mobile Digital Media																																																													
V	2005	Uplander	Body	Navigation Radio																																																													
V	2005	Uplander	Body	Navigation Radio																																																													
V	2005	Uplander	Body	Radio																																																													
V	2005	Uplander	Body	Right Power Sliding Door Module																																																													

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
V	2005	Uplander	Body	Supplemental Inflatable Restraint																																																										
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																										
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																										
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																										
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																										
V	2006	ALL	Chassis	Electronic Brake Control Module																																																										
V	2006	ALL	Body	Body Control Module																																																										
V	2006	ALL	Body	Disc Player and Video																																																										
V	2006	ALL	Body	Digital Radio Receiver																																																										
V	2006	ALL	Body	HVAC Control Module																																																										
V	2006	ALL	Body	Instrument Panel Cluster																																																										
V	2006	ALL	Body	Left Power Sliding Door Module																																																										
V	2006	ALL	Body	Mobile Digital Media																																																										
V	2006	ALL	Body	Navigation Radio																																																										
V	2006	ALL	Body	Navigation Radio																																																										
V	2006	ALL	Body	Radio																																																										
V	2006	ALL	Body	Right Power Sliding Door Module																																																										
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																										
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
V	2007	ALL	Chassis	Electronic Brake Control Module																																																										
V	2007	ALL	Body	Body Control Module																																																										
V	2007	ALL	Body	Digital Radio Receiver																																																										
V	2007	ALL	Body	Disc Player and Video Display																																																										
V	2007	ALL	Body	HVAC Control Module																																																										
V	2007	ALL	Body	Left Power Sliding Door Module																																																										
V	2007	ALL	Body	Mobile Digital Media																																																										
V	2007	ALL	Body	Radio																																																										
V	2007	ALL	Body	Navigation Radio																																																										
V	2007	ALL	Body	Right Power Sliding Door Module																																																										
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																										
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																										
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																										
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																										
V	2008	ALL	Chassis	Electronic Brake Control Module																																																										
V	2008	ALL	Body	Body Control Module																																																										
V	2008	ALL	Body	Digital Radio Receiver																																																										
V	2008	ALL	Body	Disc Player and Video Display																																																										
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																																										
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																										
V	2008	ALL	Body	Left Power Sliding Door Module																																																										
V	2008	ALL	Body	Radio																																																										
V	2008	ALL	Body	Navigation Radio																																																										
V	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
V	2008	ALL	Body	Right Power Sliding Door Module																																																										
V	2009	ALL	Powertrain	Engine Control Module																																																										
V	2009	ALL	Powertrain	Transmission Control Module																																																										
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																										
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																										
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
V	2009	ALL	Body	Body Control Module																																																											
V	2009	ALL	Body	Digital Radio Receiver																																																											
V	2009	ALL	Body	Disc Player and Video Display																																																											
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																																											
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																											
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																											
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																											
V	2009	ALL	Body	Left Power Sliding Door Module																																																											
V	2009	ALL	Body	Radio																																																											
V	2009	ALL	Body	Remote Control Door Lock Receiver																																																											
V	2009	ALL	Body	Right Power Sliding Door Module																																																											
X	2004	ALL	Powertrain	Engine Control Module																																																											
X	2004	ALL	Powertrain	Transmission Control Module																																																											
X	2004	ALL	Body	Digital Radio Receiver																																																											
X	2004	ALL	Body	Driver Information Center																																																											
X	2004	ALL	Body	Instrument Panel Cluster																																																											
X	2004	ALL	Body	Radio																																																											
X	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
X	2004	ALL	Body	Vehicle Theft Deterrent																																																											
X	2005	ALL	Powertrain	Engine Control Module																																																											
X	2005	ALL	Powertrain	Transmission Control Module																																																											
X	2005	ALL	Chassis	Electronic Brake Control Module																																																											
X	2005	ALL	Body	Body Control Module																																																											
X	2005	ALL	Body	Disc Player and Video																																																											
X	2005	ALL	Body	Digital Radio Receiver																																																											
X	2005	ALL	Body	HVAC Control Module																																																											
X	2005	ALL	Body	Instrument Panel Cluster																																																											
X	2005	ALL	Body	Left Power Sliding Door Module																																																											
X	2005	ALL	Body	Mobile Digital Media																																																											
X	2005	ALL	Body	Navigation Radio																																																											
X	2005	ALL	Body	Navigation Radio																																																											
X	2005	ALL	Body	Radio																																																											
X	2005	ALL	Body	Right Power Sliding Door Module																																																											
X	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																											
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																											
X	2006	ALL	Chassis	Electronic Brake Control Module																																																											
X	2006	ALL	Body	Body Control Module																																																											
X	2006	ALL	Body	Disc Player and Video																																																											
X	2006	ALL	Body	Digital Radio Receiver																																																											
X	2006	ALL	Body	HVAC Control Module																																																											
X	2006	ALL	Body	Instrument Panel Cluster																																																											
X	2006	ALL	Body	Left Power Sliding Door Module																																																											
X	2006	ALL	Body	Mobile Digital Media																																																											
X	2006	ALL	Body	Navigation Radio																																																											
X	2006	ALL	Body	Navigation Radio																																																											
X	2006	ALL	Body	Radio																																																											
X	2006	ALL	Body	Right Power Sliding Door Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module		

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
A	2008	HHR Panel	Body	Instrument Panel Cluster																																																											
A	2008	HHR Panel	Body	Radio																																																												
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																																												
A	2008	HHR Panel	Body	Theft Deterrent Module																																																												
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																																												
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																																												
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																												
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																												
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																												
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																												
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																												
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																												
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																																												
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2009	HHR	Chassis	Power Steering Control Module																																																												
A	2009	HHR	Chassis	Power Steering Control Module																																																												
A	2009	HHR	Body	Body Control Module																																																												
A	2009	HHR	Body	Digital Radio Receiver																																																												
A	2009	HHR	Body	Instrument Panel Cluster																																																												
A	2009	HHR	Body	Radio																																																												
A	2009	HHR	Body	Supplemental Inflatable Restraint																																																												
A	2009	HHR	Body	Theft Deterrent Module																																																												
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																																												
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																																												
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																												
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																												
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																												
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																												
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																												
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2009	HHR Panel	Chassis	Power Steering Control Module																																																												
A	2009	HHR Panel	Body	Body Control Module																																																												
A	2009	HHR Panel	Body	Digital Radio Receiver																																																												
A	2009	HHR Panel	Body	Instrument Panel Cluster																																																												
A	2009	HHR Panel	Body	Radio																																																												
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																																												
A	2009	HHR Panel	Body	Theft Deterrent Module																																																												
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																												
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																												
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																												
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																												
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																												
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																												
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																																												
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																																												
A	2010	HHR	Chassis	Power Steering Control Module																																																												
A	2010	HHR	Chassis	Power Steering Control Module																																																												
A	2010	HHR	Body	Body Control Module																																																												
A	2010	HHR	Body	Digital Radio Receiver																																																												
A	2010	HHR	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
A	2010	HHR	Body	Radio																																																															
A	2010	HHR	Body	Supplemental Inflatable Restraint																																																															
A	2010	HHR	Body	Theft Deterrent Module																																																															
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																																																																
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																																																
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																																																
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																																																
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																																
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																																
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																																
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																																
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																																
A	2010	HHR Panel	Chassis	Power Steering Control Module																																																																
A	2010	HHR Panel	Body	Body Control Module																																																																
A	2010	HHR Panel	Body	Digital Radio Receiver																																																																
A	2010	HHR Panel	Body	Instrument Panel Cluster																																																																
A	2010	HHR Panel	Body	Radio																																																																
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																																																
A	2010	HHR Panel	Body	Theft Deterrent Module																																																																
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																																
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																																
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																																
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																																
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																																																
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																																																
A	2011	HHR	Chassis	Power Steering Control Module																																																																
A	2011	HHR	Body	Body Control Module																																																																
A	2011	HHR	Body	Digital Radio Receiver																																																																
A	2011	HHR	Body	Instrument Panel Cluster																																																																
A	2011	HHR	Body	Radio																																																																
A	2011	HHR	Body	Supplemental Inflatable Restraint																																																																
A	2011	HHR	Body	Theft Deterrent Module																																																																
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																																																
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																																																
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																																																
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																																																
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																																																
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																																																
A	2011	HHR Panel	Chassis	Power Steering Control Module																																																																
A	2011	HHR Panel	Body	Body Control Module																																																																
A	2011	HHR Panel	Body	Digital Radio Receiver																																																																
A	2011	HHR Panel	Body	Instrument Panel Cluster																																																																
A	2011	HHR Panel	Body	Radio																																																																
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																																																
A	2011	HHR Panel	Body	Theft Deterrent Module																																																																
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																																
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																																
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																																
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																																
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																																
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																											
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																											
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																											
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																											
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																											
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																											
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																											
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																											
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																											
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																											
A	2013	Trax	Chassis	Electronic Brake Control Module																																																											
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																											
A	2013	Trax	Chassis	Power Steering Control Module																																																											
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																											
A	2013	Trax	Body	Body Control Module																																																										
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
A	2013	Trax	Body	Passenger Presence Module																																																											
A	2013	Trax	Body	Instrument Cluster																																																											
A	2013	Trax	Body	Radio																																																											
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																											
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																											
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																											
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																											
A	2013	Trax	Body	Front Seat Heating Control Module																																																											
A	2013	Trax	Body	Parking Assist Control Module																																																											
A	2013	Trax	Body	Frontview Camera Module																																																											
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																											
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																											
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																											
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																											
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2014	Trax	Powertrain	Fuel Injector Control Module																																																													
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																													
A	2014	Trax	Chassis	Electronic Brake Control Module																																																													
A	2014	Trax	Chassis	Power Steering Control Module																																																													
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2014	Trax	Body	Body Control Module																																																													
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2014	Trax	Body	Passenger Presence Module																																																													
A	2014	Trax	Body	Instrument Cluster																																																													
A	2014	Trax	Body	Radio																																																												
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																												
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																												
A	2014	Trax	Body	Front Seat Heating Control Module																																																												
A	2014	Trax	Body	Parking Assist Control Module																																																												
A	2014	Trax	Body	Frontview Camera Module																																																												
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																												
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																												
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																												
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																												
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																												
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																												
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2015	Trax	Powertrain	Fuel Injector Control Module																																																												
A	2015	Trax	Powertrain	Chassis Control Module																																																												
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
A	2015	Trax	Chassis	Electronic Brake Control Module																																																												
A	2015	Trax	Chassis	Power Steering Control Module																																																												
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2015	Trax	Body	Body Control Module																																																												
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2015	Trax	Body	Passenger Presence Module																																																												
A	2015	Trax	Body	Instrument Cluster																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
A	2015	Trax	Body	Radio																																																															
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																																
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																																
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																																
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																																
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																																
A	2015	Trax	Body	Seat Memory Control Module																																																																
A	2015	Trax	Body	Front Seat Heating Control Module																																																																
A	2015	Trax	Body	Right Side Object Detection Control Module																																																																
A	2015	Trax	Body	Left Side Object Detection Control Module																																																																
A	2015	Trax	Body	Parking Assist Control Module																																																																
A	2015	Trax	Body	Frontview Camera Module																																																																
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																																
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																																
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																																
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																																
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																																
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																																
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																																
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																																
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																																
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																																
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																																
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																																
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																																
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																																
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																																
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																																
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																																
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																																
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																																
A	2016	Trax	Powertrain	Fuel Injector Control Module																																																																
A	2016	Trax	Powertrain	Chassis Control Module																																																																
A	2016	Trax	Chassis	Electronic Brake Control Module																																																																
A	2016	Trax	Chassis	Power Steering Control Module																																																																
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																																
A	2016	Trax	Body	Body Control Module																																																																
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
A	2016	Trax	Body	Passenger Presence Module																																																																
A	2016	Trax	Body	Instrument Cluster																																																																
A	2016	Trax	Body	Trailer Interface Control Module																																																																
A	2016	Trax	Body	Radio																																																																
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																																
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																																
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																																
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																																
A	2016	Trax	Body	Seat Memory Control Module																																																																
A	2016	Trax	Body	Front Seat Heating Control Module																																																																
A	2016	Trax	Body	Right Side Object Detection Control Module																																																																
A	2016	Trax	Body	Left Side Object Detection Control Module																																																																
A	2016	Trax	Body	Parking Assist Control Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
A	2016	Trax	Body	Frontview Camera Module																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																															
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																															
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																															
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																															
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																															
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																															
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																																
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																																
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																															
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																															
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																															
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																															
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																															
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																															
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																															
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																															
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																															
C	2004	ALL	Chassis	ESC																																																															
C	2004	ALL	Chassis	Rear Wheel Steering																																																															
C	2004	ALL	Chassis	Tire Pressure Monitor																																																															
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																															
C	2004	ALL	Chassis	VSES																																																															
C	2004	ALL	Body	Amplifier (Bose)																																																															
C	2004	ALL	Body	Body Control Module																																																															
C	2004	ALL	Body	CD Changer																																																															
C	2004	ALL	Body	Chime																																																															
C	2004	ALL	Body	Driver Door Module																																																															
C	2004	ALL	Body	Driver Seat Module																																																															
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																															
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																															
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																															
C	2004	ALL	Body	Instrument Panel Cluster																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2004	ALL	Body	OnStar																																																										
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Radio Base																																																										
C	2004	ALL	Body	Radio Uplevel																																																										
C	2004	ALL	Body	Radio Navigation																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																										
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																										
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2004	ALL	Body	Vehicle Theft Deterrent																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2005	ALL	Chassis	ESC																																																										
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2005	ALL	Chassis	VSES																																																															
C	2005	ALL	Body	Amplifier (Bose)																																																															
C	2005	ALL	Body	Body Control Module																																																															
C	2005	ALL	Body	CD Changer																																																															
C	2005	ALL	Body	Chime																																																															
C	2005	ALL	Body	Disc Player and Video Display																																																															
C	2005	ALL	Body	Driver Door Module																																																															
C	2005	ALL	Body	Driver Seat Module																																																															
C	2005	ALL	Body	Generator Battery Control Module																																																															
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																															
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																															
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																															
C	2005	ALL	Body	Instrument Panel Cluster																																																															
C	2005	ALL	Body	Passenger Door Module																																																															
C	2005	ALL	Body	Passenger Presence System																																																															
C	2005	ALL	Body	Base Radio																																																															
C	2005	ALL	Body	Uplevel Radio																																																															
C	2005	ALL	Body	Navigation Radio																																																															
C	2005	ALL	Body	Rear Aux. Climate Module																																																															
C	2005	ALL	Body	Rear HVAC																																																															
C	2005	ALL	Body	Rear Seat Audio																																																															
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																															
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																															
C	2005	ALL	Body	Vehicle Theft Deterrent																																																															
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																																
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																																
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																																
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																																
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																																
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																																
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																																
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																																
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																																
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																																
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																																
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																																
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																																
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																																
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																																
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																																
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																																
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																																
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																																
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																																
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																												
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																													
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																													
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																													
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																														
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																													
C	2006	ALL	Chassis	ESC																																																													
C	2006	ALL	Chassis	Tire Pressure Monitor																																																													
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																													
C	2006	ALL	Chassis	VSES																																																													
C	2006	ALL	Body	Amplifier (Bose)																																																													
C	2006	ALL	Body	Body Control Module																																																													
C	2006	ALL	Body	CD Changer																																																													
C	2006	ALL	Body	Chime																																																													
C	2006	ALL	Body	Disc Player and Video Display																																																													
C	2006	ALL	Body	Driver Door Module																																																													
C	2006	ALL	Body	Driver Seat Module																																																													
C	2006	ALL	Body	Generator Battery Control Module																																																													
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																													
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																													
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																													
C	2006	ALL	Body	Instrument Panel Cluster																																																													
C	2006	ALL	Body	Passenger Door Module																																																													
C	2006	ALL	Body	Passenger Presence System																																																													
C	2006	ALL	Body	Base Radio																																																													
C	2006	ALL	Body	Uplevel Radio																																																													
C	2006	ALL	Body	Navigation Radio																																																													
C	2006	ALL	Body	Rear Aux. Climate Module																																																													
C	2006	ALL	Body	Rear HVAC																																																													
C	2006	ALL	Body	Rear Seat Audio																																																													
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																													
C	2006	ALL	Body	Vehicle Theft Deterrent																																																													
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																													
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																													
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2007	Avalanche	Chassis	Electronic Suspension Control																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																																														
C	2007	Avalanche	Body	Amplifier (Bose)																																																															
C	2007	Avalanche	Body	Assist Step Controller																																																															
C	2007	Avalanche	Body	Body Control Module																																																															
C	2007	Avalanche	Body	Body Control Module (aux.)																																																															
C	2007	Avalanche	Body	Digital Radio Receiver																																																															
C	2007	Avalanche	Body	Driver Door Switch																																																															
C	2007	Avalanche	Body	HVAC Control Module Auto																																																															
C	2007	Avalanche	Body	HVAC Control Module Manual																																																															
C	2007	Avalanche	Body	Instrument Panel Cluster																																																															
C	2007	Avalanche	Body	Memory Seat Module																																																															
C	2007	Avalanche	Body	Park Assist Module																																																															
C	2007	Avalanche	Body	Passenger Door Switch																																																															
C	2007	Avalanche	Body	Passenger Presence System																																																															
C	2007	Avalanche	Body	Radio																																																															
C	2007	Avalanche	Body	Rear Heated Seat Module																																																															
C	2007	Avalanche	Body	Rear HVAC/RSA																																																															
C	2007	Avalanche	Body	Rollover Sensor																																																															
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																															
C	2007	Avalanche	Body	Theft Deterrent Module																																																															
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																															
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																															
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																															
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																															
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																															
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																															
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2007	Suburban	Chassis	Electronic Suspension Control																																																															
C	2007	Suburban	Chassis	Trailer Brake Control Module																																																															
C	2007	Suburban	Body	Amplifier (Bose)																																																															
C	2007	Suburban	Body	Assist Step Controller																																																															
C	2007	Suburban	Body	Body Control Module																																																															
C	2007	Suburban	Body	Body Control Module (aux.)																																																															
C	2007	Suburban	Body	Digital Radio Receiver																																																															
C	2007	Suburban	Body	Driver Door Switch																																																															
C	2007	Suburban	Body	HVAC Control Module Auto																																																															
C	2007	Suburban	Body	HVAC Control Module Manual																																																															
C	2007	Suburban	Body	Instrument Panel Cluster																																																															
C	2007	Suburban	Body	Lift Gate Module																																																															
C	2007	Suburban	Body	Memory Seat Module																																																															
C	2007	Suburban	Body	Park Assist Module																																																															
C	2007	Suburban	Body	Passenger Door Switch																																																															
C	2007	Suburban	Body	Passenger Presence System																																																															
C	2007	Suburban	Body	Radio																																																															
C	2007	Suburban	Body	Rear Heated Seat Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2007	Suburban	Body	Rear HVAC/RSA																																																												
C	2007	Suburban	Body	Rollover Sensor																																																													
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																																													
C	2007	Suburban	Body	Theft Deterrent Module																																																													
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																													
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																													
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																													
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																													
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2007	Silverado	Chassis	Electronic Suspension Control																																																													
C	2007	Silverado	Chassis	Trailer Brake Control Module																																																													
C	2007	Silverado	Body	Amplifier (Bose)																																																													
C	2007	Silverado	Body	Body Control Module																																																													
C	2007	Silverado	Body	Body Control Module (aux.)																																																													
C	2007	Silverado	Body	Digital Radio Receiver																																																													
C	2007	Silverado	Body	Driver Door Switch																																																													
C	2007	Silverado	Body	HVAC Control Module Auto																																																													
C	2007	Silverado	Body	HVAC Control Module Manual																																																													
C	2007	Silverado	Body	Instrument Panel Cluster																																																													
C	2007	Silverado	Body	Memory Seat Module																																																													
C	2007	Silverado	Body	Park Assist Module																																																													
C	2007	Silverado	Body	Passenger Door Switch																																																													
C	2007	Silverado	Body	Passenger Presence System																																																													
C	2007	Silverado	Body	Radio																																																													
C	2007	Silverado	Body	Rear Heated Seat Module																																																													
C	2007	Silverado	Body	Rear HVAC/RSA																																																													
C	2007	Silverado	Body	Rollover Sensor																																																													
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																																													
C	2007	Silverado	Body	Theft Deterrent Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2007	Tahoe	Chassis	Electronic Suspension Control																																																													
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																																													
C	2007	Tahoe	Body	Amplifier (Bose)																																																													
C	2007	Tahoe	Body	Assist Step Controller																																																													
C	2007	Tahoe	Body	Body Control Module																																																													
C	2007	Tahoe	Body	Body Control Module (aux.)																																																													
C	2007	Tahoe	Body	Digital Radio Receiver																																																													
C	2007	Tahoe	Body	Driver Door Switch																																																													
C	2007	Tahoe	Body	HVAC Control Module Auto																																																													
C	2007	Tahoe	Body	HVAC Control Module Manual																																																													
C	2007	Tahoe	Body	Instrument Panel Cluster																																																													
C	2007	Tahoe	Body	Lift Gate Module																																																													
C	2007	Tahoe	Body	Memory Seat Module																																																													
C	2007	Tahoe	Body	Park Assist Module																																																													
C	2007	Tahoe	Body	Passenger Door Switch																																																													
C	2007	Tahoe	Body	Passenger Presence System																																																													
C	2007	Tahoe	Body	Radio																																																													
C	2007	Tahoe	Body	Rear Heated Seat Module																																																													
C	2007	Tahoe	Body	Rear HVAC/RSA																																																													
C	2007	Tahoe	Body	Rollover Sensor																																																													
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																													
C	2007	Tahoe	Body	Theft Deterrent Module																																																													
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																													
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
C	2008	Avalanche	Chassis	Electronic Brake Control Module																																																													
C	2008	Avalanche	Chassis	Electronic Suspension Control																																																													
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																																													
C	2008	Avalanche	Body	Amplifier (Bose)																																																													
C	2008	Avalanche	Body	Assist Step Controller																																																													
C	2008	Avalanche	Body	Body Control Module																																																													
C	2008	Avalanche	Body	Body Control Module (aux.)																																																													
C	2008	Avalanche	Body	Digital Radio Receiver																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2008	Avalanche	Body	Driver Door Switch																																																											
C	2008	Avalanche	Body	HVAC Control Module Auto																																																												
C	2008	Avalanche	Body	HVAC Control Module Manual																																																												
C	2008	Avalanche	Body	Instrument Panel Cluster																																																												
C	2008	Avalanche	Body	Memory Seat Module																																																												
C	2008	Avalanche	Body	Park Assist Module																																																												
C	2008	Avalanche	Body	Passenger Door Switch																																																												
C	2008	Avalanche	Body	Passenger Presence System																																																												
C	2008	Avalanche	Body	Radio																																																												
C	2008	Avalanche	Body	Rear Heated Seat Module																																																												
C	2008	Avalanche	Body	Rear HVAC/RSA																																																												
C	2008	Avalanche	Body	Rollover Sensor																																																												
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																												
C	2008	Avalanche	Body	Theft Deterrent Module																																																												
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Suburban	Chassis	Electronic Suspension Control																																																												
C	2008	Suburban	Chassis	Trailer Brake Control Module																																																												
C	2008	Suburban	Body	Amplifier (Bose)																																																												
C	2008	Suburban	Body	Assist Step Controller																																																												
C	2008	Suburban	Body	Body Control Module																																																												
C	2008	Suburban	Body	Body Control Module (aux.)																																																												
C	2008	Suburban	Body	Digital Radio Receiver																																																												
C	2008	Suburban	Body	Driver Door Switch																																																												
C	2008	Suburban	Body	HVAC Control Module Auto																																																												
C	2008	Suburban	Body	HVAC Control Module Manual																																																												
C	2008	Suburban	Body	Instrument Panel Cluster																																																												
C	2008	Suburban	Body	Lift Gate Module																																																												
C	2008	Suburban	Body	Memory Seat Module																																																												
C	2008	Suburban	Body	Park Assist Module																																																												
C	2008	Suburban	Body	Passenger Door Switch																																																												
C	2008	Suburban	Body	Passenger Presence System																																																												
C	2008	Suburban	Body	Radio																																																												
C	2008	Suburban	Body	Rear Heated Seat Module																																																												
C	2008	Suburban	Body	Rear HVAC/RSA																																																												
C	2008	Suburban	Body	Rollover Sensor																																																												
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2008	Suburban	Body	Theft Deterrent Module																																																															
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																																
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																																
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																																
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																																
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																																
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																																
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																																
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																																
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																																
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																																
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																																
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																																
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																																
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																																
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																																
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																																
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																																
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																																
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																																
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																																
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																																
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																																
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																																
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																																
C	2008	Silverado	Chassis	Electronic Suspension Control																																																																
C	2008	Silverado	Chassis	Trailer Brake Control Module																																																																
C	2008	Silverado	Body	Amplifier (Bose)																																																																
C	2008	Silverado	Body	Body Control Module																																																																
C	2008	Silverado	Body	Body Control Module (aux.)																																																																
C	2008	Silverado	Body	Digital Radio Receiver																																																																
C	2008	Silverado	Body	Driver Door Switch																																																																
C	2008	Silverado	Body	HVAC Control Module Auto																																																																
C	2008	Silverado	Body	HVAC Control Module Manual																																																																
C	2008	Silverado	Body	Instrument Panel Cluster																																																																
C	2008	Silverado	Body	Memory Seat Module																																																																
C	2008	Silverado	Body	Park Assist Module																																																																
C	2008	Silverado	Body	Passenger Door Switch																																																																
C	2008	Silverado	Body	Passenger Presence System																																																																
C	2008	Silverado	Body	Radio																																																																
C	2008	Silverado	Body	Rear Heated Seat Module																																																																
C	2008	Silverado	Body	Rear HVAC/RSA																																																																
C	2008	Silverado	Body	Rollover Sensor																																																																
C	2008	Silverado	Body	Supplemental Inflatable Restraint																																																																
C	2008	Silverado	Body	Theft Deterrent Module																																																																
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																																																
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																															
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																																
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
C	2008	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2008	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																																											
C	2008	Tahoe	Body	Amplifier (Bose)																																																											
C	2008	Tahoe	Body	Assist Step Controller																																																											
C	2008	Tahoe	Body	Body Control Module																																																											
C	2008	Tahoe	Body	Body Control Module (aux.)																																																											
C	2008	Tahoe	Body	Digital Radio Receiver																																																											
C	2008	Tahoe	Body	Driver Door Switch																																																											
C	2008	Tahoe	Body	HVAC Control Module Auto																																																											
C	2008	Tahoe	Body	HVAC Control Module Manual																																																											
C	2008	Tahoe	Body	Instrument Panel Cluster																																																											
C	2008	Tahoe	Body	Memory Seat Module																																																											
C	2008	Tahoe	Body	Park Assist Module																																																											
C	2008	Tahoe	Body	Passenger Presence System																																																											
C	2008	Tahoe	Body	Radio																																																											
C	2008	Tahoe	Body	Rear Heated Seat Module																																																											
C	2008	Tahoe	Body	Rear HVAC/RSA																																																											
C	2008	Tahoe	Body	Rollover Sensor																																																											
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																											
C	2008	Tahoe	Body	Theft Deterrent Module																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																										
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module			V																																																								
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module				V																																																							
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																											
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2008	Tahoe Hybrid	Body	Body Control Module																																																											
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																											
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																																											
C	2008	Tahoe Hybrid	Body	HVAC Control Module																																																											
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																											
C	2008	Tahoe Hybrid	Body	Memory Seat Module																																																											
C	2008	Tahoe Hybrid	Body	Park Assist Module																																																											
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2008	Tahoe Hybrid	Body	Radio																																																															
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																															
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																															
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																																															
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																															
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																															
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																															
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																															
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																															
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																															
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																															
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																															
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																															
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																															
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																															
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																															
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																															
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																															
C	2009	Avalanche	Chassis	Electronic Brake Control Module																																																															
C	2009	Avalanche	Chassis	Electronic Suspension Control																																																															
C	2009	Avalanche	Chassis	Trailer Brake Control Module																																																															
C	2009	Avalanche	Body	Amplifier (Bose)																																																															
C	2009	Avalanche	Body	Assist Step Controller																																																															
C	2009	Avalanche	Body	Body Control Module																																																															
C	2009	Avalanche	Body	Body Control Module (aux.)																																																															
C	2009	Avalanche	Body	Digital Radio Receiver																																																															
C	2009	Avalanche	Body	Driver Door Switch																																																															
C	2009	Avalanche	Body	HVAC Control Module Auto																																																															
C	2009	Avalanche	Body	HVAC Control Module Manual																																																															
C	2009	Avalanche	Body	Instrument Panel Cluster																																																															
C	2009	Avalanche	Body	Memory Seat Module																																																															
C	2009	Avalanche	Body	Park Assist Module																																																															
C	2009	Avalanche	Body	Passenger Door Switch																																																															
C	2009	Avalanche	Body	Passenger Presence System																																																															
C	2009	Avalanche	Body	Radio																																																															
C	2009	Avalanche	Body	Rear Heated Seat Module																																																															
C	2009	Avalanche	Body	Rear HVAC/RSA																																																															
C	2009	Avalanche	Body	Rollover Sensor																																																															
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																															
C	2009	Avalanche	Body	Theft Deterrent Module																																																															
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																															
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																															
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																															
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																												
C	2009	Cheyenne	Body	Amplifier (Bose)																																																												
C	2009	Cheyenne	Body	Body Control Module (aux.)																																																												
C	2009	Cheyenne	Body	Digital Radio Receiver																																																												
C	2009	Cheyenne	Body	Driver Door Switch																																																												
C	2009	Cheyenne	Body	Instrument Panel Cluster																																																												
C	2009	Cheyenne	Body	Park Assist Module																																																												
C	2009	Cheyenne	Body	Passenger Door Switch																																																												
C	2009	Cheyenne	Body	Passenger Presence System																																																												
C	2009	Cheyenne	Body	Rear Heated Seat Module																																																												
C	2009	Cheyenne	Body	Rear HVAC/RSA																																																												
C	2009	Cheyenne	Body	Rollover Sensor																																																												
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																												
C	2009	Cheyenne	Body	Theft Deterrent Module																																																												
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																																							
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																												
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2009	Suburban	Chassis	Electronic Suspension Control																																																												
C	2009	Suburban	Chassis	Trailer Brake Control Module																																																												
C	2009	Suburban	Body	Amplifier (Bose)																																																												
C	2009	Suburban	Body	Assist Step Controller																																																												
C	2009	Suburban	Body	Body Control Module																																																												
C	2009	Suburban	Body	Body Control Module (aux.)																																																												
C	2009	Suburban	Body	Digital Radio Receiver																																																												
C	2009	Suburban	Body	Driver Door Switch																																																												
C	2009	Suburban	Body	HVAC Control Module Auto																																																												
C	2009	Suburban	Body	HVAC Control Module Manual																																																												
C	2009	Suburban	Body	Instrument Panel Cluster																																																												
C	2009	Suburban	Body	Left Side Object Detection Module																																																												
C	2009	Suburban	Body	Lift Gate Module																																																												
C	2009	Suburban	Body	Memory Seat Module																																																												
C	2009	Suburban	Body	Park Assist Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2009	Suburban	Body	Passenger Door Switch																																																														
C	2009	Suburban	Body	Passenger Presence System																																																															
C	2009	Suburban	Body	Radio																																																															
C	2009	Suburban	Body	Rear Heated Seat Module																																																															
C	2009	Suburban	Body	Rear HVAC/RSA																																																															
C	2009	Suburban	Body	Right Side Object Detection Module																																																															
C	2009	Suburban	Body	Rollover Sensor																																																															
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																																															
C	2009	Suburban	Body	Theft Deterrent Module																																																															
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																															
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																															
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																															
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																															
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																															
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																															
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																															
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																															
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																															
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																															
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																																										
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual					V																																																										
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																															
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																															
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																															
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																															
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																															
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																															
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																															
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																															
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																															
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																															
C	2009	Silverado	Chassis	Electronic Suspension Control																																																															
C	2009	Silverado	Chassis	Trailer Brake Control Module																																																															
C	2009	Silverado	Body	Amplifier (Bose)																																																															
C	2009	Silverado	Body	Body Control Module																																																															
C	2009	Silverado	Body	Body Control Module (aux.)																																																															
C	2009	Silverado	Body	Digital Radio Receiver																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2009	Silverado	Body	Driver Door Switch																																																															
C	2009	Silverado	Body	HVAC Control Module Auto																																																															
C	2009	Silverado	Body	HVAC Control Module Manual																																																															
C	2009	Silverado	Body	Instrument Panel Cluster																																																															
C	2009	Silverado	Body	Memory Seat Module																																																															
C	2009	Silverado	Body	Park Assist Module																																																															
C	2009	Silverado	Body	Passenger Door Switch																																																															
C	2009	Silverado	Body	Passenger Presence System																																																															
C	2009	Silverado	Body	Radio																																																															
C	2009	Silverado	Body	Rear Heated Seat Module																																																															
C	2009	Silverado	Body	Rear HVAC/RSA																																																															
C	2009	Silverado	Body	Rollover Sensor																																																															
C	2009	Silverado	Body	Supplemental Inflatable Restraint																																																															
C	2009	Silverado	Body	Theft Deterrent Module																																																															
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																															
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																															
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																															
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																															
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																													
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																														
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																															
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																															
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module			V																																																											
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																															
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module				V																																																										
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																															
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																															
C	2009	Silverado Hybrid	Body	Body Control Module																																																															
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																															
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																															
C	2009	Silverado Hybrid	Body	Driver Door Switch																																																															
C	2009	Silverado Hybrid	Body	HVAC Control Module																																																															
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																															
C	2009	Silverado Hybrid	Body	Memory Seat Module																																																															
C	2009	Silverado Hybrid	Body	Park Assist Module																																																															
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																																															
C	2009	Silverado Hybrid	Body	Passenger Presence System																																																															
C	2009	Silverado Hybrid	Body	Radio																																																															
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																															
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																															
C	2009	Silverado Hybrid	Body	Rollover Sensor																																																															
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																															
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																															
C	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																															
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																															
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																															
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																															
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2009	Tahoe	Chassis	Electronic Brake Control Module																																																											
C	2009	Tahoe	Chassis	Electronic Suspension Control																																																											
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																																											
C	2009	Tahoe	Body	Amplifier (Bose)																																																											
C	2009	Tahoe	Body	Assist Step Controller																																																											
C	2009	Tahoe	Body	Body Control Module																																																											
C	2009	Tahoe	Body	Body Control Module (aux.)																																																											
C	2009	Tahoe	Body	Digital Radio Receiver																																																											
C	2009	Tahoe	Body	Driver Door Switch																																																											
C	2009	Tahoe	Body	HVAC Control Module Auto																																																											
C	2009	Tahoe	Body	HVAC Control Module Manual																																																											
C	2009	Tahoe	Body	Instrument Panel Cluster																																																											
C	2009	Tahoe	Body	Left Side Object Detection Module																																																											
C	2009	Tahoe	Body	Lift Gate Module																																																											
C	2009	Tahoe	Body	Memory Seat Module																																																											
C	2009	Tahoe	Body	Park Assist Module																																																											
C	2009	Tahoe	Body	Passenger Door Switch																																																											
C	2009	Tahoe	Body	Passenger Presence System																																																											
C	2009	Tahoe	Body	Radio																																																										
C	2009	Tahoe	Body	Rear Heated Seat Module																																																											
C	2009	Tahoe	Body	Rear HVAC/RSA																																																											
C	2009	Tahoe	Body	Right Side Object Detection Module																																																											
C	2009	Tahoe	Body	Rollover Sensor																																																											
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																											
C	2009	Tahoe	Body	Theft Deterrent Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																									
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module			V																																																								
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module				V																																																							
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																											
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
C	2009	Tahoe Hybrid	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																																
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																																
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																																																
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																																																
C	2009	Tahoe Hybrid	Body	HVAC Control Module																																																																
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																																
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																																
C	2009	Tahoe Hybrid	Body	Park Assist Module																																																																
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																																
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																																																
C	2009	Tahoe Hybrid	Body	Radio																																																																
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																																
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																																
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																																
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																																																
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																																
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																																
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																																
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																																
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																																
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																																
C	2010	Avalanche	Chassis	Electronic Brake Control Module																																																																
C	2010	Avalanche	Chassis	Electronic Suspension Control																																																																
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																																
C	2010	Avalanche	Body	Amplifier (Bose)																																																																
C	2010	Avalanche	Body	Assist Step Controller																																																																
C	2010	Avalanche	Body	Body Control Module																																																																
C	2010	Avalanche	Body	Body Control Module (aux.)																																																																
C	2010	Avalanche	Body	Digital Radio Receiver																																																																
C	2010	Avalanche	Body	Driver Door Switch																																																																
C	2010	Avalanche	Body	HVAC Control Module Auto																																																																
C	2010	Avalanche	Body	HVAC Control Module Manual																																																																
C	2010	Avalanche	Body	Instrument Panel Cluster																																																																
C	2010	Avalanche	Body	Memory Seat Module																																																																
C	2010	Avalanche	Body	Park Assist Module																																																																
C	2010	Avalanche	Body	Passenger Door Switch																																																																
C	2010	Avalanche	Body	Passenger Presence System																																																																
C	2010	Avalanche	Body	Radio																																																																
C	2010	Avalanche	Body	Rear Heated Seat Module																																																																
C	2010	Avalanche	Body	Rear HVAC/RSA																																																																
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																																
C	2010	Avalanche	Body	Theft Deterrent Module																																																																
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																																
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																																
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																														
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																														
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																														
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Cheyenne	Body	Amplifier (Bose)																																																														
C	2010	Cheyenne	Body	Body Control Module (aux.)																																																														
C	2010	Cheyenne	Body	Digital Radio Receiver																																																														
C	2010	Cheyenne	Body	Driver Door Switch																																																														
C	2010	Cheyenne	Body	Instrument Panel Cluster																																																														
C	2010	Cheyenne	Body	Park Assist Module																																																														
C	2010	Cheyenne	Body	Passenger Door Switch																																																														
C	2010	Cheyenne	Body	Passenger Presence System																																																														
C	2010	Cheyenne	Body	Rear Heated Seat Module																																																														
C	2010	Cheyenne	Body	Rear HVAC/RSA																																																														
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																														
C	2010	Cheyenne	Body	Theft Deterrent Module																																																														
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
C	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																														
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																														
C	2010	Suburban	Chassis	Electronic Suspension Control																																																														
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Suburban	Body	Amplifier (Bose)																																																														
C	2010	Suburban	Body	Assist Step Controller																																																														
C	2010	Suburban	Body	Body Control Module																																																														
C	2010	Suburban	Body	Body Control Module (aux.)																																																														
C	2010	Suburban	Body	Digital Radio Receiver																																																														
C	2010	Suburban	Body	Driver Door Switch																																																														
C	2010	Suburban	Body	HVAC Control Module Auto																																																														
C	2010	Suburban	Body	HVAC Control Module Manual																																																														
C	2010	Suburban	Body	Instrument Panel Cluster																																																														
C	2010	Suburban	Body	Left Side Object Detection Module																																																														
C	2010	Suburban	Body	Lift Gate Module																																																														
C	2010	Suburban	Body	Memory Seat Module																																																														
C	2010	Suburban	Body	Park Assist Module																																																														
C	2010	Suburban	Body	Passenger Door Switch																																																														
C	2010	Suburban	Body	Passenger Presence System																																																														
C	2010	Suburban	Body	Radio																																																														
C	2010	Suburban	Body	Rear Heated Seat Module																																																														
C	2010	Suburban	Body	Rear HVAC/RSA																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2010	Suburban	Body	Right Side Object Detection Module																																																														
C	2010	Suburban	Body	Supplemental Inflatable Restraint																																																														
C	2010	Suburban	Body	Theft Deterrent Module																																																														
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																															
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																															
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																															
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																															
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																															
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																															
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																															
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																															
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																															
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																															
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																															
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																															
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																															
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																															
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																															
C	2010	Silverado	Chassis	Electronic Suspension Control																																																															
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																															
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																															
C	2010	Silverado	Body	Amplifier (Bose)																																																															
C	2010	Silverado	Body	Body Control Module																																																															
C	2010	Silverado	Body	Body Control Module (aux.)																																																															
C	2010	Silverado	Body	Digital Radio Receiver																																																															
C	2010	Silverado	Body	Driver Door Switch																																																															
C	2010	Silverado	Body	HVAC Control Module Auto																																																															
C	2010	Silverado	Body	HVAC Control Module Manual																																																															
C	2010	Silverado	Body	Instrument Panel Cluster																																																															
C	2010	Silverado	Body	Memory Seat Module																																																															
C	2010	Silverado	Body	Park Assist Module																																																															
C	2010	Silverado	Body	Passenger Door Switch																																																															
C	2010	Silverado	Body	Passenger Presence System																																																															
C	2010	Silverado	Body	Radio																																																															
C	2010	Silverado	Body	Rear Heated Seat Module																																																															
C	2010	Silverado	Body	Rear HVAC/RSA																																																															
C	2010	Silverado	Body	Supplemental Inflatable Restraint																																																															
C	2010	Silverado	Body	Theft Deterrent Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																											
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module			V																																																										
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																														
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module				V																																																									
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																														
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																														
C	2010	Silverado Hybrid	Body	Body Control Module																																																														
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																														
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																														
C	2010	Silverado Hybrid	Body	Driver Door Switch																																																														
C	2010	Silverado Hybrid	Body	Heated Seat Module																																																														
C	2010	Silverado Hybrid	Body	HVAC Control Module																																																														
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																														
C	2010	Silverado Hybrid	Body	Park Assist Module																																																														
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																																														
C	2010	Silverado Hybrid	Body	Passenger Presence System																																																														
C	2010	Silverado Hybrid	Body	Radio																																																														
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																														
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																														
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																														
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																														
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																														
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2010	Tahoe	Chassis	Electronic Brake Control Module																																																														
C	2010	Tahoe	Chassis	Electronic Suspension Control																																																														
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Tahoe	Body	Amplifier (Bose)																																																														
C	2010	Tahoe	Body	Assist Step Controller																																																														
C	2010	Tahoe	Body	Body Control Module																																																														
C	2010	Tahoe	Body	Body Control Module (aux.)																																																														
C	2010	Tahoe	Body	Digital Radio Receiver																																																														
C	2010	Tahoe	Body	Driver Door Switch																																																														
C	2010	Tahoe	Body	HVAC Control Module Auto																																																														
C	2010	Tahoe	Body	HVAC Control Module Manual																																																														
C	2010	Tahoe	Body	Instrument Panel Cluster																																																														
C	2010	Tahoe	Body	Left Side Object Detection Module																																																														
C	2010	Tahoe	Body	Lift Gate Module																																																														
C	2010	Tahoe	Body	Memory Seat Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2010	Tahoe	Body	Park Assist Module																																																															
C	2010	Tahoe	Body	Passenger Door Switch																																																															
C	2010	Tahoe	Body	Passenger Presence System																																																															
C	2010	Tahoe	Body	Radio																																																															
C	2010	Tahoe	Body	Rear Heated Seat Module																																																															
C	2010	Tahoe	Body	Rear HVAC/RSA																																																															
C	2010	Tahoe	Body	Right Side Object Detection Module																																																															
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																															
C	2010	Tahoe	Body	Theft Deterrent Module																																																															
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																															
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																															
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																															
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																															
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																													
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																														
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																														
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module			V																																																											
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																															
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module				V																																																											
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																															
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																															
C	2010	Tahoe Hybrid	Body	Body Control Module																																																															
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																															
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																															
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																																															
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																																															
C	2010	Tahoe Hybrid	Body	HVAC Control Module																																																															
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																															
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																															
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																																															
C	2010	Tahoe Hybrid	Body	Park Assist Module																																																															
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																															
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																																															
C	2010	Tahoe Hybrid	Body	Radio																																																															
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																															
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																															
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																															
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																															
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																															
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																															
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2011	Avalanche	Chassis	Electronic Brake Control Module																																																															
C	2011	Avalanche	Chassis	Electronic Suspension Control																																																															
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2011	Avalanche	Body	Amplifier (Bose)																																																												
C	2011	Avalanche	Body	Assist Step Controller																																																													
C	2011	Avalanche	Body	Body Control Module																																																													
C	2011	Avalanche	Body	Body Control Module (aux.)																																																													
C	2011	Avalanche	Body	Digital Radio Receiver																																																													
C	2011	Avalanche	Body	Driver Door Switch																																																													
C	2011	Avalanche	Body	HVAC Control Module Auto																																																													
C	2011	Avalanche	Body	HVAC Control Module Manual																																																													
C	2011	Avalanche	Body	Instrument Panel Cluster																																																													
C	2011	Avalanche	Body	Memory Seat Module																																																													
C	2011	Avalanche	Body	Park Assist Module																																																													
C	2011	Avalanche	Body	Passenger Door Switch																																																													
C	2011	Avalanche	Body	Passenger Presence System																																																													
C	2011	Avalanche	Body	Radio																																																													
C	2011	Avalanche	Body	Rear Heated Seat Module																																																													
C	2011	Avalanche	Body	Rear HVAC/RSA																																																													
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																													
C	2011	Avalanche	Body	Theft Deterrent Module																																																													
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																													
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																													
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																													
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																													
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																													
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																													
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																													
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																													
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																													
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																													
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																													
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																													
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																													
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																													
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																													
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																													
C	2011	Captiva	Chassis	Electronic Brake Control Module																																																													
C	2011	Captiva	Chassis	Parking Brake Control Module																																																													
C	2011	Captiva	Body	Body Control Module																																																													
C	2011	Captiva	Body	Auxiliary Body Control Module																																																													
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2011	Captiva	Body	Instrument Cluster																																																													
C	2011	Captiva	Body	Headlamp Control Module						V																																																						
C	2011	Captiva	Body	HVAC Control Module																																																													
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																																													
C	2011	Captiva	Body	Parking Assist Control Module																																																													
C	2011	Captiva	Body	Theft Deterrent Module																																																													
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																															
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																															
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																															
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																																															
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																															
C	2011	Cheyenne	Body	Amplifier (Bose)																																																															
C	2011	Cheyenne	Body	Body Control Module																																																															
C	2011	Cheyenne	Body	Body Control Module (aux.)																																																															
C	2011	Cheyenne	Body	Digital Radio Receiver																																																															
C	2011	Cheyenne	Body	Driver Door Switch																																																															
C	2011	Cheyenne	Body	Instrument Panel Cluster																																																															
C	2011	Cheyenne	Body	Park Assist Module																																																															
C	2011	Cheyenne	Body	Passenger Door Switch																																																															
C	2011	Cheyenne	Body	Passenger Presence System																																																															
C	2011	Cheyenne	Body	Rear Heated Seat Module																																																															
C	2011	Cheyenne	Body	Rear HVAC/RSA																																																															
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																															
C	2011	Cheyenne	Body	Theft Deterrent Module																																																															
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																															
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																															
C	2011	Suburban	Chassis	Electronic Suspension Control																																																															
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																															
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																															
C	2011	Suburban	Body	Amplifier (Bose)																																																															
C	2011	Suburban	Body	Assist Step Controller																																																															
C	2011	Suburban	Body	Body Control Module																																																															
C	2011	Suburban	Body	Body Control Module (aux.)																																																															
C	2011	Suburban	Body	Digital Radio Receiver																																																															
C	2011	Suburban	Body	Driver Door Switch																																																															
C	2011	Suburban	Body	HVAC Control Module Auto																																																															
C	2011	Suburban	Body	HVAC Control Module Manual																																																															
C	2011	Suburban	Body	Instrument Panel Cluster																																																															
C	2011	Suburban	Body	Left Side Object Detection Module																																																															
C	2011	Suburban	Body	Lift Gate Module																																																															
C	2011	Suburban	Body	Memory Seat Module																																																															
C	2011	Suburban	Body	Park Assist Module																																																															
C	2011	Suburban	Body	Passenger Door Switch																																																															
C	2011	Suburban	Body	Passenger Presence System																																																															
C	2011	Suburban	Body	Radio																																																															
C	2011	Suburban	Body	Rear Heated Seat Module																																																															
C	2011	Suburban	Body	Rear HVAC/RSA																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2011	Suburban	Body	Right Side Object Detection Module																																																																
C	2011	Suburban	Body	Supplemental Inflatable Restraint																																																																
C	2011	Suburban	Body	Theft Deterrent Module																																																																
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																																
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																																
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																																
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																																
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																																
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																																
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																																
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																																
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																																
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																																
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																																
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																																
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																																
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																																
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																																
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																			
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module															V	V	V																																													
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																																
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																																
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																			
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																													
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																																
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																																
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																																
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																																
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																																
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																																
C	2011	Silverado	Chassis	Electronic Suspension Control																																																																
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																																
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																																
C	2011	Silverado	Body	Amplifier (Bose)																																																																
C	2011	Silverado	Body	Body Control Module																																																																
C	2011	Silverado	Body	Body Control Module (aux.)																																																																
C	2011	Silverado	Body	Digital Radio Receiver																																																																
C	2011	Silverado	Body	Driver Door Switch																																																																
C	2011	Silverado	Body	HVAC Control Module Auto																																																																
C	2011	Silverado	Body	HVAC Control Module Manual																																																																
C	2011	Silverado	Body	Instrument Panel Cluster																																																																
C	2011	Silverado	Body	Memory Seat Module																																																																
C	2011	Silverado	Body	Park Assist Module																																																																
C	2011	Silverado	Body	Passenger Door Switch																																																																
C	2011	Silverado	Body	Passenger Presence System																																																																
C	2011	Silverado	Body	Radio																																																																
C	2011	Silverado	Body	Rear Heated Seat Module																																																																
C	2011	Silverado	Body	Rear HVAC/RSA																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																																															
C	2011	Silverado	Body	Theft Deterrent Module																																																															
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																															
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																															
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																															
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																															
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																													
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																														
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																														
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module			V																																																											
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																															
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module				V																																																										
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																															
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																															
C	2011	Silverado Hybrid	Body	Body Control Module																																																															
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																															
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																															
C	2011	Silverado Hybrid	Body	Driver Door Switch																																																															
C	2011	Silverado Hybrid	Body	Heated Seat Module																																																															
C	2011	Silverado Hybrid	Body	HVAC Control Module																																																															
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																															
C	2011	Silverado Hybrid	Body	Park Assist Module																																																															
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																																															
C	2011	Silverado Hybrid	Body	Passenger Presence System																																																															
C	2011	Silverado Hybrid	Body	Radio																																																															
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																															
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																															
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																															
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																															
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																															
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2011	Tahoe	Chassis	Electronic Brake Control Module																																																															
C	2011	Tahoe	Chassis	Electronic Suspension Control																																																															
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																															
C	2011	Tahoe	Body	Amplifier (Bose)																																																															
C	2011	Tahoe	Body	Assist Step Controller																																																															
C	2011	Tahoe	Body	Body Control Module																																																															
C	2011	Tahoe	Body	Body Control Module (aux.)																																																															
C	2011	Tahoe	Body	Digital Radio Receiver																																																															
C	2011	Tahoe	Body	Driver Door Switch																																																															
C	2011	Tahoe	Body	HVAC Control Module Auto																																																															
C	2011	Tahoe	Body	HVAC Control Module Manual																																																															
C	2011	Tahoe	Body	Instrument Panel Cluster																																																															
C	2011	Tahoe	Body	Left Side Object Detection Module																																																															
C	2011	Tahoe	Body	Lift Gate Module																																																															
C	2011	Tahoe	Body	Memory Seat Module																																																															
C	2011	Tahoe	Body	Park Assist Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2011	Tahoe	Body	Passenger Door Switch																																																											
C	2011	Tahoe	Body	Passenger Presence System																																																												
C	2011	Tahoe	Body	Radio																																																												
C	2011	Tahoe	Body	Rear Heated Seat Module																																																												
C	2011	Tahoe	Body	Rear HVAC/RSA																																																												
C	2011	Tahoe	Body	Right Side Object Detection Module																																																												
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																												
C	2011	Tahoe	Body	Theft Deterrent Module																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																											
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module			V																																																									
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																													
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module				V																																																									
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																													
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																													
C	2011	Tahoe Hybrid	Body	Body Control Module																																																													
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																													
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																													
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																																													
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																																													
C	2011	Tahoe Hybrid	Body	HVAC Control Module																																																													
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																													
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																													
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																																													
C	2011	Tahoe Hybrid	Body	Park Assist Module																																																													
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																													
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																																													
C	2011	Tahoe Hybrid	Body	Radio																																																													
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																													
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																													
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																													
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																													
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																													
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																													
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																													
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																													
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2012	Avalanche	Chassis	Electronic Brake Control Module																																																													
C	2012	Avalanche	Chassis	Electronic Suspension Control																																																													
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																													
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2012	Avalanche	Body	Amplifier (Bose)																																																												
C	2012	Avalanche	Body	Assist Step Controller																																																													
C	2012	Avalanche	Body	Body Control Module																																																													
C	2012	Avalanche	Body	Body Control Module (aux.)																																																													
C	2012	Avalanche	Body	Digital Radio Receiver																																																													
C	2012	Avalanche	Body	Driver Door Switch																																																													
C	2012	Avalanche	Body	HVAC Control Module Auto																																																													
C	2012	Avalanche	Body	HVAC Control Module Manual																																																													
C	2012	Avalanche	Body	Instrument Panel Cluster																																																													
C	2012	Avalanche	Body	Memory Seat Module																																																													
C	2012	Avalanche	Body	Navigation Radio																																																													
C	2012	Avalanche	Body	Park Assist Module																																																													
C	2012	Avalanche	Body	Passenger Door Switch																																																													
C	2012	Avalanche	Body	Passenger Presence System																																																													
C	2012	Avalanche	Body	Radio																																																													
C	2012	Avalanche	Body	Rear Heated Seat Module																																																													
C	2012	Avalanche	Body	Rear HVAC/RSA																																																													
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																													
C	2012	Avalanche	Body	Theft Deterrent Module																																																													
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																													
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																													
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																													
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																													
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																													
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																													
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																													
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																													
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																													
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																													
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																													
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																													
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																													
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																													
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																													
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																													
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																													
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																													
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																													
C	2012	Captiva	Chassis	Electronic Brake Control Module																																																													
C	2012	Captiva	Chassis	Parking Brake Control Module																																																													
C	2012	Captiva	Body	Body Control Module																																																													
C	2012	Captiva	Body	Auxiliary Body Control Module																																																													
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2012	Captiva	Body	Instrument Cluster																																																													
C	2012	Captiva	Body	Headlamp Control Module						V																																																						
C	2012	Captiva	Body	HVAC Control Module																																																													
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																																													
C	2012	Captiva	Body	Parking Assist Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2012	Captiva	Body	Theft Deterrent Module																																																															
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																																
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																																
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																																
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																																
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																																
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																																
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																																
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																																
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																																
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																																
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																																																
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																																
C	2012	Cheyenne	Body	Amplifier (Bose)																																																																
C	2012	Cheyenne	Body	Body Control Module																																																																
C	2012	Cheyenne	Body	Body Control Module (aux.)																																																																
C	2012	Cheyenne	Body	Digital Radio Receiver																																																																
C	2012	Cheyenne	Body	Driver Door Switch																																																																
C	2012	Cheyenne	Body	Instrument Panel Cluster																																																																
C	2012	Cheyenne	Body	Park Assist Module																																																																
C	2012	Cheyenne	Body	Passenger Door Switch																																																																
C	2012	Cheyenne	Body	Passenger Presence System																																																																
C	2012	Cheyenne	Body	Rear Heated Seat Module																																																																
C	2012	Cheyenne	Body	Rear HVAC/RSA																																																																
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																																
C	2012	Cheyenne	Body	Theft Deterrent Module																																																																
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																																
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																																
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																																
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																																
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																																
C	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																																
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																																
C	2012	Suburban	Chassis	Electronic Suspension Control																																																																
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																																
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																																
C	2012	Suburban	Body	Amplifier (Bose)																																																																
C	2012	Suburban	Body	Assist Step Controller																																																																
C	2012	Suburban	Body	Body Control Module																																																																
C	2012	Suburban	Body	Body Control Module (aux.)																																																																
C	2012	Suburban	Body	Digital Radio Receiver																																																																
C	2012	Suburban	Body	Driver Door Switch																																																																
C	2012	Suburban	Body	HVAC Control Module Auto																																																																
C	2012	Suburban	Body	HVAC Control Module Manual																																																																
C	2012	Suburban	Body	Instrument Panel Cluster																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2012	Suburban	Body	Left Side Object Detection Module																																																												
C	2012	Suburban	Body	Lift Gate Module																																																													
C	2012	Suburban	Body	Memory Seat Module																																																													
C	2012	Suburban	Body	Navigation Radio																																																													
C	2012	Suburban	Body	Park Assist Module																																																													
C	2012	Suburban	Body	Passenger Door Switch																																																													
C	2012	Suburban	Body	Passenger Presence System																																																													
C	2012	Suburban	Body	Radio																																																													
C	2012	Suburban	Body	Rear Heated Seat Module																																																													
C	2012	Suburban	Body	Rear HVAC/RSA																																																													
C	2012	Suburban	Body	Right Side Object Detection Module																																																													
C	2012	Suburban	Body	Supplemental Inflatable Restraint																																																													
C	2012	Suburban	Body	Theft Deterrent Module																																																													
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																													
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																													
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																													
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																													
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																													
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																													
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module															V	V	V																																											
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																													
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																													
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																											
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																													
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																													
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																													
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													
C	2012	Silverado	Chassis	Electronic Suspension Control																																																													
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																													
C	2012	Silverado	Body	Amplifier (Bose)																																																													
C	2012	Silverado	Body	Body Control Module																																																													
C	2012	Silverado	Body	Body Control Module (aux.)																																																													
C	2012	Silverado	Body	Digital Radio Receiver																																																													
C	2012	Silverado	Body	Driver Door Switch																																																													
C	2012	Silverado	Body	HVAC Control Module Auto																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2012	Silverado	Body	HVAC Control Module Manual																																																														
C	2012	Silverado	Body	Instrument Panel Cluster																																																															
C	2012	Silverado	Body	Memory Seat Module																																																															
C	2012	Silverado	Body	Navigation Radio																																																															
C	2012	Silverado	Body	Park Assist Module																																																															
C	2012	Silverado	Body	Passenger Door Switch																																																															
C	2012	Silverado	Body	Passenger Presence System																																																															
C	2012	Silverado	Body	Radio																																																															
C	2012	Silverado	Body	Rear Heated Seat Module																																																															
C	2012	Silverado	Body	Rear HVAC/RSA																																																															
C	2012	Silverado	Body	Supplemental Inflatable Restraint																																																															
C	2012	Silverado	Body	Theft Deterrent Module																																																															
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																																
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																																
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																																
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																																
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																														
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																															
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																															
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																															
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module			V																																																											
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																															
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module				V																																																											
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																															
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																															
C	2012	Silverado Hybrid	Body	Body Control Module																																																															
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																															
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																															
C	2012	Silverado Hybrid	Body	Driver Door Switch																																																															
C	2012	Silverado Hybrid	Body	Heated Seat Module																																																															
C	2012	Silverado Hybrid	Body	HVAC Control Module																																																															
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																															
C	2012	Silverado Hybrid	Body	Navigation Radio																																																															
C	2012	Silverado Hybrid	Body	Park Assist Module																																																															
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																																															
C	2012	Silverado Hybrid	Body	Passenger Presence System																																																															
C	2012	Silverado Hybrid	Body	Radio																																																															
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																															
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																															
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																															
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																															
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																															
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2012	Tahoe	Chassis	Electronic Brake Control Module																																																															
C	2012	Tahoe	Chassis	Electronic Suspension Control																																																															
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																															
C	2012	Tahoe	Body	Amplifier (Bose)																																																															
C	2012	Tahoe	Body	Assist Step Controller																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2012	Tahoe	Body	Body Control Module																																																										
C	2012	Tahoe	Body	Body Control Module (aux.)																																																										
C	2012	Tahoe	Body	Digital Radio Receiver																																																										
C	2012	Tahoe	Body	Driver Door Switch																																																										
C	2012	Tahoe	Body	HVAC Control Module Auto																																																										
C	2012	Tahoe	Body	HVAC Control Module Manual																																																										
C	2012	Tahoe	Body	Instrument Panel Cluster																																																										
C	2012	Tahoe	Body	Left Side Object Detection Module																																																										
C	2012	Tahoe	Body	Lift Gate Module																																																										
C	2012	Tahoe	Body	Memory Seat Module																																																										
C	2012	Tahoe	Body	Navigation Radio																																																										
C	2012	Tahoe	Body	Park Assist Module																																																										
C	2012	Tahoe	Body	Passenger Door Switch																																																										
C	2012	Tahoe	Body	Passenger Presence System																																																										
C	2012	Tahoe	Body	Radio																																																										
C	2012	Tahoe	Body	Rear Heated Seat Module																																																										
C	2012	Tahoe	Body	Rear HVAC/RSA																																																										
C	2012	Tahoe	Body	Right Side Object Detection Module																																																										
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																										
C	2012	Tahoe	Body	Theft Deterrent Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																										
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module			V																																																							
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																										
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module				V																																																						
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																										
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																										
C	2012	Tahoe Hybrid	Body	Body Control Module																																																										
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																										
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																										
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																																										
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																																										
C	2012	Tahoe Hybrid	Body	HVAC Control Module																																																										
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																										
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																										
C	2012	Tahoe Hybrid	Body	Lift Gate Module																																																										
C	2012	Tahoe Hybrid	Body	Navigation Radio																																																										
C	2012	Tahoe Hybrid	Body	Park Assist Module																																																										
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																										
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																																										
C	2012	Tahoe Hybrid	Body	Radio																																																										
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																										
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																										
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																														
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																														
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																														
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2013	Avalanche	Chassis	Electronic Brake Control Module																																																														
C	2013	Avalanche	Chassis	Electronic Suspension Control																																																														
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																														
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																														
C	2013	Avalanche	Body	Amplifier (Bose)																																																														
C	2013	Avalanche	Body	Assist Step Controller																																																														
C	2013	Avalanche	Body	Body Control Module																																																														
C	2013	Avalanche	Body	Body Control Module (aux.)																																																														
C	2013	Avalanche	Body	Digital Radio Receiver																																																														
C	2013	Avalanche	Body	Driver Door Switch																																																														
C	2013	Avalanche	Body	HVAC Control Module Auto																																																														
C	2013	Avalanche	Body	HVAC Control Module Manual																																																														
C	2013	Avalanche	Body	Instrument Panel Cluster																																																														
C	2013	Avalanche	Body	Memory Seat Module																																																														
C	2013	Avalanche	Body	Navigation Radio																																																														
C	2013	Avalanche	Body	Park Assist Module																																																														
C	2013	Avalanche	Body	Passenger Door Switch																																																														
C	2013	Avalanche	Body	Passenger Presence System																																																														
C	2013	Avalanche	Body	Radio																																																														
C	2013	Avalanche	Body	Rear Heated Seat Module																																																														
C	2013	Avalanche	Body	Rear HVAC/RSA																																																														
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																														
C	2013	Avalanche	Body	Theft Deterrent Module																																																														
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																														
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																														
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																														
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																														
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																														
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																														
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																														
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																														
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																														
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																														
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																														
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																														
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																														
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																														
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																														
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																														
C	2013	Captiva	Chassis	Electronic Brake Control Module																																																														
C	2013	Captiva	Chassis	Parking Brake Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																														
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																															
C	2013	Captiva	Body	Auxiliary Body Control Module																																																															
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
C	2013	Captiva	Body	Instrument Cluster																																																															
C	2013	Captiva	Body	Headlamp Control Module						V																																																									
C	2013	Captiva	Body	HVAC Control Module																																																															
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																															
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																		V	V	V																																									
C	2013	Captiva	Body	Theft Deterrent Module																																																															
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																															
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																															
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																															
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																															
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																															
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																															
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																																															
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																															
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																															
C	2013	Cheyenne	Body	Amplifier (Bose)																																																															
C	2013	Cheyenne	Body	Body Control Module																																																															
C	2013	Cheyenne	Body	Body Control Module (aux.)																																																															
C	2013	Cheyenne	Body	Digital Radio Receiver																																																															
C	2013	Cheyenne	Body	Driver Door Switch																																																															
C	2013	Cheyenne	Body	Instrument Panel Cluster																																																															
C	2013	Cheyenne	Body	Park Assist Module																																																															
C	2013	Cheyenne	Body	Passenger Door Switch																																																															
C	2013	Cheyenne	Body	Passenger Presence System																																																															
C	2013	Cheyenne	Body	Rear Heated Seat Module																																																															
C	2013	Cheyenne	Body	Rear HVAC/RSA																																																															
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																															
C	2013	Cheyenne	Body	Theft Deterrent Module																																																															
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																															
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																															
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																															
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
C	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																															
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2013	Suburban	Chassis	Electronic Suspension Control																																																															
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																														
C	2013	Suburban	Body	Amplifier (Bose)																																																															
C	2013	Suburban	Body	Assist Step Controller																																																															
C	2013	Suburban	Body	Body Control Module																																																															
C	2013	Suburban	Body	Body Control Module (aux.)																																																															
C	2013	Suburban	Body	Digital Radio Receiver																																																															
C	2013	Suburban	Body	Driver Door Switch																																																															
C	2013	Suburban	Body	HVAC Control Module Auto																																																															
C	2013	Suburban	Body	HVAC Control Module Manual																																																															
C	2013	Suburban	Body	Instrument Panel Cluster																																																															
C	2013	Suburban	Body	Left Side Object Detection Module																																																															
C	2013	Suburban	Body	Lift Gate Module																																																															
C	2013	Suburban	Body	Memory Seat Module																																																															
C	2013	Suburban	Body	Navigation Radio																																																															
C	2013	Suburban	Body	Park Assist Module																																																															
C	2013	Suburban	Body	Passenger Door Switch																																																															
C	2013	Suburban	Body	Passenger Presence System																																																															
C	2013	Suburban	Body	Radio																																																															
C	2013	Suburban	Body	Rear Heated Seat Module																																																															
C	2013	Suburban	Body	Rear HVAC/RSA																																																															
C	2013	Suburban	Body	Right Side Object Detection Module																																																															
C	2013	Suburban	Body	Supplemental Inflatable Restraint																																																															
C	2013	Suburban	Body	Theft Deterrent Module																																																															
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																															
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																															
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																															
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																															
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																															
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																															
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																															
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																															
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																															
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V	V	V					V							V																																									
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module															V	V	V																																												
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																															
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																															
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																														
C	2013	Silverado	Chassis	Electronic Suspension Control																																																															
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																															
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																															
C	2013	Silverado	Body	Amplifier (Bose)																																																															
C	2013	Silverado	Body	Body Control Module																																																															
C	2013	Silverado	Body	Body Control Module (aux.)																																																															
C	2013	Silverado	Body	Digital Radio Receiver																																																															
C	2013	Silverado	Body	Driver Door Switch																																																															
C	2013	Silverado	Body	HVAC Control Module Auto																																																															
C	2013	Silverado	Body	HVAC Control Module Manual																																																															
C	2013	Silverado	Body	Instrument Panel Cluster																																																															
C	2013	Silverado	Body	Memory Seat Module																																																															
C	2013	Silverado	Body	Navigation Radio																																																															
C	2013	Silverado	Body	Park Assist Module																																																															
C	2013	Silverado	Body	Passenger Door Switch																																																															
C	2013	Silverado	Body	Passenger Presence System																																																															
C	2013	Silverado	Body	Radio																																																															
C	2013	Silverado	Body	Rear Heated Seat Module																																																															
C	2013	Silverado	Body	Rear HVAC/RSA																																																															
C	2013	Silverado	Body	Supplemental Inflatable Restraint																																																															
C	2013	Silverado	Body	Theft Deterrent Module																																																															
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																															
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																															
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																															
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																															
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																													
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																														
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																															
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																															
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module			V																																																												
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																															
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module				V																																																											
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																															
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																															
C	2013	Silverado Hybrid	Body	Body Control Module																																																															
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																															
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																															
C	2013	Silverado Hybrid	Body	Driver Door Switch																																																															
C	2013	Silverado Hybrid	Body	Heated Seat Module																																																															
C	2013	Silverado Hybrid	Body	HVAC Control Module																																																															
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																															
C	2013	Silverado Hybrid	Body	Navigation Radio																																																															
C	2013	Silverado Hybrid	Body	Park Assist Module																																																															
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																																															
C	2013	Silverado Hybrid	Body	Passenger Presence System																																																															
C	2013	Silverado Hybrid	Body	Radio																																																															
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																															
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																																
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																																
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																																
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
C	2013	Tahoe	Chassis	Electronic Brake Control Module																																																																
C	2013	Tahoe	Chassis	Electronic Suspension Control																																																																
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																																
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																																
C	2013	Tahoe	Body	Amplifier (Bose)																																																																
C	2013	Tahoe	Body	Assist Step Controller																																																																
C	2013	Tahoe	Body	Body Control Module																																																																
C	2013	Tahoe	Body	Body Control Module (aux.)																																																																
C	2013	Tahoe	Body	Digital Radio Receiver																																																																
C	2013	Tahoe	Body	Driver Door Switch																																																																
C	2013	Tahoe	Body	HVAC Control Module Auto																																																																
C	2013	Tahoe	Body	HVAC Control Module Manual																																																																
C	2013	Tahoe	Body	Instrument Panel Cluster																																																																
C	2013	Tahoe	Body	Left Side Object Detection Module																																																																
C	2013	Tahoe	Body	Lift Gate Module																																																																
C	2013	Tahoe	Body	Memory Seat Module																																																																
C	2013	Tahoe	Body	Navigation Radio																																																																
C	2013	Tahoe	Body	Park Assist Module																																																																
C	2013	Tahoe	Body	Passenger Door Switch																																																																
C	2013	Tahoe	Body	Passenger Presence System																																																																
C	2013	Tahoe	Body	Radio																																																																
C	2013	Tahoe	Body	Rear Heated Seat Module																																																																
C	2013	Tahoe	Body	Rear HVAC/RSA																																																																
C	2013	Tahoe	Body	Right Side Object Detection Module																																																																
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																																
C	2013	Tahoe	Body	Theft Deterrent Module																																																																
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																																
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																																
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																																
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																																
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																														
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																															
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																															
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																															
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module			V																																																												
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																																
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module				V																																																											
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																																
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																																
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																																
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																																
C	2013	Tahoe Hybrid	Body	Body Control Module																																																																
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																																
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																																
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																																															
C	2013	Tahoe Hybrid	Body	HVAC Control Module																																																															
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																															
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																															
C	2013	Tahoe Hybrid	Body	Lift Gate Module																																																															
C	2013	Tahoe Hybrid	Body	Navigation Radio																																																															
C	2013	Tahoe Hybrid	Body	Park Assist Module																																																															
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																															
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																																															
C	2013	Tahoe Hybrid	Body	Radio																																																															
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																															
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																															
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																															
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																															
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																															
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																															
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																															
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																															
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																															
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																															
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																															
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																															
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																															
C	2014	Captiva (3GN)	Body	Body Control Module																																																															
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
C	2014	Captiva (3GN)	Body	Passenger Presence Module																																																															
C	2014	Captiva (3GN)	Body	Instrument Cluster																						V																																								
C	2014	Captiva (3GN)	Body	Radio																																																															
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																															
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																															
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																															
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																															
C	2014	Captiva (3GN)	Body	HVAC Control Module																																																															
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																															
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																															
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																															
C	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																															
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																															
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																															
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																															
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																															
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																															
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																															
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																															
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																															
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																															
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																															
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																															
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																															
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																															
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																											
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																											
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																											
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Captiva (Other)	Body	Instrument Cluster																																																											
C	2014	Captiva (Other)	Body	Headlamp Control Module						V																																																					
C	2014	Captiva (Other)	Body	HVAC Control Module																																																											
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																		V	V	V																																						
C	2014	Captiva (Other)	Body	Theft Deterrent Module																																																											
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																						V																																				
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																											
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																																											
C	2014	Cheyenne	Chassis	Power Steering Control Module																																																											
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2014	Cheyenne	Body	Body Control Module																																																											
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Cheyenne	Body	Passenger Presence Module																																																											
C	2014	Cheyenne	Body	Instrument Cluster																																																											
C	2014	Cheyenne	Body	Radio Control																																																											
C	2014	Cheyenne	Body	HVAC Control																																																											
C	2014	Cheyenne	Body	Radio																																																											
C	2014	Cheyenne	Body	Amplifier																																																											
C	2014	Cheyenne	Body	Media Disc Player																																																											
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																																											
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																											
C	2014	Cheyenne	Body	HVAC Control Module																																																											
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																											
C	2014	Cheyenne	Body	Parking Assist Control Module																																																											
C	2014	Cheyenne	Body	Frontview Camera Module																																																											
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																							V																																			
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																											
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
C	2014	Silverado	Chassis	Electronic Brake Control Module																																																											
C	2014	Silverado	Chassis	Parking Brake Control Module																																																											
C	2014	Silverado	Chassis	Power Steering Control Module																																																											
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																											
C	2014	Silverado	Body	Body Control Module																																																											
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Silverado	Body	Passenger Presence Module																																																											
C	2014	Silverado	Body	Instrument Cluster																																																											
C	2014	Silverado	Body	Radio Control																																																											
C	2014	Silverado	Body	HVAC Control																																																											
C	2014	Silverado	Body	Radio																																																											
C	2014	Silverado	Body	Amplifier																																																											
C	2014	Silverado	Body	Media Disc Player																																																											
C	2014	Silverado	Body	Human Machine Interface Control Module																																																											
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																											
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																											
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																											
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																											
C	2014	Silverado	Body	Parking Assist Control Module																																																											
C	2014	Silverado	Body	Frontview Camera Module																																																											
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																											
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																						V																																					
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																						V																																					
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module							V																	V	V	V	V	V	V	V	V																												
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																							V																																				
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																											
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																											
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																											
C	2014	Silverado HD	Chassis	Suspension Control Module																																																											
C	2014	Silverado HD	Body	Body Control Module																																																											
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
C	2014	Silverado HD	Body	Passenger Presence Module																																																											
C	2014	Silverado HD	Body	Instrument Cluster																																																											
C	2014	Silverado HD	Body	Chime Alarm Control Module																																																											
C	2014	Silverado HD	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2014	Silverado HD	Body	Navigation Radio																																																											
C	2014	Silverado HD	Body	Uplevel Radio																																																												
C	2014	Silverado HD	Body	Amplifier																																																												
C	2014	Silverado HD	Body	Rear Audio Control Module																																																												
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																												
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																																												
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																												
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																												
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																												
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																												
C	2014	Silverado HD	Body	Seat Memory Control Module																																																												
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																												
C	2014	Silverado HD	Body	Parking Assist Control Module																																																												
C	2014	Silverado HD	Body	Theft Deterrent Module																																																												
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																												
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																												
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																												
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																												
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2014	Suburban	Chassis	Electronic Brake Control Module																																																												
C	2014	Suburban	Chassis	Parking Brake Control Module																																																												
C	2014	Suburban	Chassis	Suspension Control Module																																																												
C	2014	Suburban	Body	Body Control Module																																																												
C	2014	Suburban	Body	Auxiliary Body Control Module																																																												
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2014	Suburban	Body	Passenger Presence Module																																																												
C	2014	Suburban	Body	Instrument Cluster																																																												
C	2014	Suburban	Body	Base Radio																																																												
C	2014	Suburban	Body	Navigation Radio																																																												
C	2014	Suburban	Body	Uplevel Radio																																																												
C	2014	Suburban	Body	Amplifier																																																												
C	2014	Suburban	Body	Rear Audio Control Module																																																												
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																																												
C	2014	Suburban	Body	Personal Audio Link Control Module																																																												
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																												
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																												
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																												
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																												
C	2014	Suburban	Body	Liftgate Control Module																																																												
C	2014	Suburban	Body	Seat Memory Control Module																																																												
C	2014	Suburban	Body	Rear Seat Heating Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2014	Suburban	Body	Assist Step Control Module																																																																
C	2014	Suburban	Body	Right Side Object Detection Control Module																																																																
C	2014	Suburban	Body	Left Side Object Detection Control Module																																																																
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																																																
C	2014	Suburban	Body	Parking Assist Control Module																																																																
C	2014	Suburban	Body	Theft Deterrent Module																																																																
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																																
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																																
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																																
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																																
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																																
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																																
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																																																
C	2014	Tahoe	Chassis	Parking Brake Control Module																																																																
C	2014	Tahoe	Chassis	Suspension Control Module																																																																
C	2014	Tahoe	Body	Body Control Module																																																																
C	2014	Tahoe	Body	Auxiliary Body Control Module																																																																
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
C	2014	Tahoe	Body	Passenger Presence Module																																																																
C	2014	Tahoe	Body	Instrument Cluster																																																																
C	2014	Tahoe	Body	Base Radio																																																																
C	2014	Tahoe	Body	Navigation Radio																																																																
C	2014	Tahoe	Body	Uplevel Radio																																																																
C	2014	Tahoe	Body	Amplifier																																																																
C	2014	Tahoe	Body	Rear Audio Control Module																																																																
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																																
C	2014	Tahoe	Body	Personal Audio Link Control Module																																																																
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																																
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																																
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																																
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																																
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																																
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																																
C	2014	Tahoe	Body	Liftgate Control Module																																																																
C	2014	Tahoe	Body	Seat Memory Control Module																																																																
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																																																
C	2014	Tahoe	Body	Assist Step Control Module																																																																
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																																																
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																																																
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																																
C	2014	Tahoe	Body	Parking Assist Control Module																																																																
C	2014	Tahoe	Body	Theft Deterrent Module																																																																
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																																
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																																
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																																
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																																
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																																
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																																
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																																
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																																
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2015	Captiva (3GN)	Body	Body Control Module																																																												
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																																													
C	2015	Captiva (3GN)	Body	Instrument Cluster																					V																																								
C	2015	Captiva (3GN)	Body	Radio																																																													
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																													
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																													
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																													
C	2015	Captiva (3GN)	Body	HVAC Control Module																																																													
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																													
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																													
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																													
C	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																													
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																													
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																													
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																													
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																													
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																													
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																													
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																													
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																													
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																													
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																													
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																													
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																													
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																													
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																													
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																													
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																													
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2015	Captiva (Other)	Body	Instrument Cluster																																																													
C	2015	Captiva (Other)	Body	Headlamp Control Module						V																																																						
C	2015	Captiva (Other)	Body	HVAC Control Module																																																													
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																													
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																		V	V	V																																							
C	2015	Captiva (Other)	Body	Theft Deterrent Module																																																													
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																													
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																													
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																													
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																						V																																							
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																													
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																													
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																													
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																												
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																													
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																													
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																													
C	2015	Cheyenne	Chassis	Power Steering Control Module																																																													
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2015	Cheyenne	Chassis	Suspension Control Module																																																													
C	2015	Cheyenne	Body	Body Control Module																																																													
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2015	Cheyenne	Body	Passenger Presence Module																																																													
C	2015	Cheyenne	Body	Instrument Cluster																																																													
C	2015	Cheyenne	Body	Radio Controls																																																													
C	2015	Cheyenne	Body	HVAC Controls																																																													
C	2015	Cheyenne	Body	Radio																																																													
C	2015	Cheyenne	Body	Amplifier																																																													
C	2015	Cheyenne	Body	Media Disc Player																																																													
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																																													
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																													
C	2015	Cheyenne	Body	HVAC Control Module																																																													
C	2015	Cheyenne	Body	Parking Assist Control Module																																																													
C	2015	Cheyenne	Body	Frontview Camera Module																																																													
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																														
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																														
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																							V																																							
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																							V																																							
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																														
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																														
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																														
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module							V																	V	V	V	V	V	V	V	V																															
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																														
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																								V																																					
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
C	2015	Silverado	Chassis	Electronic Brake Control Module																																																														
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																														
C	2015	Silverado	Chassis	Power Steering Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																															
C	2015	Silverado	Chassis	Suspension Control Module																																																																
C	2015	Silverado	Body	Body Control Module																																																																
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
C	2015	Silverado	Body	Passenger Presence Module																																																																
C	2015	Silverado	Body	Instrument Cluster																																																																
C	2015	Silverado	Body	Radio Controls																																																																
C	2015	Silverado	Body	HVAC Controls																																																																
C	2015	Silverado	Body	Radio																																																																
C	2015	Silverado	Body	Amplifier																																																																
C	2015	Silverado	Body	Media Disc Player																																																																
C	2015	Silverado	Body	Human Machine Interface Control Module																																																																
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																																																
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																																
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																																
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																																
C	2015	Silverado	Body	Parking Assist Control Module																																																																
C	2015	Silverado	Body	Frontview Camera Module																																																																
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																																
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																																
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																																
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																																
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																																
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																																
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																																
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																																
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																																
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																																
C	2015	Suburban	Chassis	Electronic Brake Control Module																																																																
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																																
C	2015	Suburban	Chassis	Parking Brake Control Module																																																																
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																																
C	2015	Suburban	Chassis	Power Steering Control Module																																																																
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																																
C	2015	Suburban	Chassis	Suspension Control Module																																																																
C	2015	Suburban	Body	Body Control Module																																																																
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
C	2015	Suburban	Body	Passenger Presence Module																																																																
C	2015	Suburban	Body	Instrument Cluster																																																																
C	2015	Suburban	Body	Radio Controls																																																																
C	2015	Suburban	Body	HVAC Controls																																																																
C	2015	Suburban	Body	Radio																																																																
C	2015	Suburban	Body	Amplifier																																																																
C	2015	Suburban	Body	Media Disc Player																																																																
C	2015	Suburban	Body	Human Machine Interface Control Module																																																																
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																																
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																																
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																																
C	2015	Suburban	Body	HVAC Control Module																																																																
C	2015	Suburban	Body	Liftgate Control Module																																																																
C	2015	Suburban	Body	Keyless Entry Control Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2015	Suburban	Body	Assist Step Control Module																																																												
C	2015	Suburban	Body	Left Side Object Detection Control Module																																																													
C	2015	Suburban	Body	Parking Assist Control Module																																																													
C	2015	Suburban	Body	Frontview Camera Module																																																													
C	2015	Suburban	Body	Steering Column Lock Control Module																																																													
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																													
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																													
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																													
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																													
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																													
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																													
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																													
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																													
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																																													
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																													
C	2015	Tahoe	Chassis	Parking Brake Control Module																																																													
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																													
C	2015	Tahoe	Chassis	Power Steering Control Module																																																													
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																													
C	2015	Tahoe	Chassis	Suspension Control Module																																																													
C	2015	Tahoe	Body	Body Control Module																																																													
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2015	Tahoe	Body	Passenger Presence Module																																																													
C	2015	Tahoe	Body	Instrument Cluster																																																													
C	2015	Tahoe	Body	Radio Controls																																																													
C	2015	Tahoe	Body	HVAC Controls																																																													
C	2015	Tahoe	Body	Radio																																																												
C	2015	Tahoe	Body	Amplifier																																																												
C	2015	Tahoe	Body	Media Disc Player																																																													
C	2015	Tahoe	Body	Human Machine Interface Control Module																																																													
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																													
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																													
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																													
C	2015	Tahoe	Body	HVAC Control Module																																																													
C	2015	Tahoe	Body	Liftgate Control Module																																																													
C	2015	Tahoe	Body	Keyless Entry Control Module																																																													
C	2015	Tahoe	Body	Assist Step Control Module																																																													
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																																													
C	2015	Tahoe	Body	Parking Assist Control Module																																																													
C	2015	Tahoe	Body	Frontview Camera Module																																																													
C	2015	Tahoe	Body	Steering Column Lock Control Module																																																													
C	2015	Tahoe	Body	Battery Energy Control Module																																																													
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																													
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																													
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																											
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																												
C	2016	Captiva (3GN)	Body	Body Control Module																																																												
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Captiva (3GN)	Body	Instrument Cluster																						V																																						
C	2016	Captiva (3GN)	Body	Radio																																																												
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																												
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																												
C	2016	Captiva (3GN)	Body	HVAC Control Module																																																												
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																												
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																												
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																												
C	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																												
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																												
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																												
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																												
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																												
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																												
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																												
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																												
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																												
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																												
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																												
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																												
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																												
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Captiva (Other)	Body	Instrument Cluster																																																												
C	2016	Captiva (Other)	Body	Headlamp Control Module						V																																																						
C	2016	Captiva (Other)	Body	Radio																																																												
C	2016	Captiva (Other)	Body	HVAC Control Module																																																												
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																												
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																												
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																		V	V	V																																						
C	2016	Captiva (Other)	Body	Theft Deterrent Module																																																												
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																												
C	2016	Cheyenne	Chassis	Power Steering Control Module																																																												
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2016	Cheyenne	Chassis	Suspension Control Module																																																												
C	2016	Cheyenne	Body	Body Control Module																																																												
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Cheyenne	Body	Passenger Presence Module																																																												
C	2016	Cheyenne	Body	Instrument Cluster																																																												
C	2016	Cheyenne	Body	Radio Controls																																																												
C	2016	Cheyenne	Body	HVAC Controls																																																												
C	2016	Cheyenne	Body	Radio																																																												
C	2016	Cheyenne	Body	Amplifier																																																												
C	2016	Cheyenne	Body	Media Disc Player																																																												
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																																												
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																												
C	2016	Cheyenne	Body	HVAC Control Module																																																												
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																												
C	2016	Cheyenne	Body	Parking Assist Control Module																																																												
C	2016	Cheyenne	Body	Frontview Camera Module																																																												
C	2016	Cheyenne	Body	Frontview Camera Module																																																												
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																													
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																													
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																													
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																													
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																													
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																													
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																													
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																V	V	V																										
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																												
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																						V																																						
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																						V																																						
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module							V																	V	V	V	V	V	V	V	V																												
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																							V																																				
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2016	Silverado	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2016	Silverado	Chassis	Power Steering Control Module																																			V	V	V																					
C	2016	Silverado	Chassis	Power Steering Control Module																																																										
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Silverado	Chassis	Suspension Control Module																																																										
C	2016	Silverado	Body	Body Control Module																																																										
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Silverado	Body	Passenger Presence Module																																																										
C	2016	Silverado	Body	Instrument Cluster																																																										
C	2016	Silverado	Body	Radio Controls																																																										
C	2016	Silverado	Body	HVAC Controls																																																										
C	2016	Silverado	Body	Radio (IO3)																																																										
C	2016	Silverado	Body	Radio (IOB)																																																										
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
C	2016	Silverado	Body	Amplifier																																																										
C	2016	Silverado	Body	Media Disc Player																																																										
C	2016	Silverado	Body	Human Machine Interface Control Module																																																										
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																										
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																										
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																										
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																										
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																																										
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																																										
C	2016	Silverado	Body	Parking Assist Control Module																																																										
C	2016	Silverado	Body	Frontview Camera Module																																																										
C	2016	Silverado	Body	Frontview Camera Module																																																										
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																						V																																				
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
C	2016	Suburban	Chassis	Electronic Brake Control Module																																																										
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																										
C	2016	Suburban	Chassis	Parking Brake Control Module																																																										
C	2016	Suburban	Chassis	Power Steering Control Module																																																										
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																										
C	2016	Suburban	Chassis	Suspension Control Module																																																										
C	2016	Suburban	Body	Body Control Module																																																										
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
C	2016	Suburban	Body	Passenger Presence Module																																																										
C	2016	Suburban	Body	Instrument Cluster																																																										
C	2016	Suburban	Body	Radio Controls																																																										
C	2016	Suburban	Body	HVAC Controls																																																										
C	2016	Suburban	Body	Radio																																																										
C	2016	Suburban	Body	Amplifier																																																										
C	2016	Suburban	Body	Media Disc Player																																																										
C	2016	Suburban	Body	Human Machine Interface Control Module																																																										
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																																										
C	2016	Suburban	Body	HVAC Control Module																																																										
C	2016	Suburban	Body	Liftgate Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																											
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																																												
C	2016	Suburban	Body	Keyless Entry Control Module																																																												
C	2016	Suburban	Body	Assist Step Control Module																																																												
C	2016	Suburban	Body	Left Side Object Detection Control Module																																																												
C	2016	Suburban	Body	Parking Assist Control Module																																																												
C	2016	Suburban	Body	Frontview Camera Module																																																												
C	2016	Suburban	Body	Steering Column Lock Control Module																																																												
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																																												
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																												
C	2016	Tahoe	Chassis	Parking Brake Control Module																																																												
C	2016	Tahoe	Chassis	Power Steering Control Module																																																												
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																												
C	2016	Tahoe	Chassis	Suspension Control Module																																																												
C	2016	Tahoe	Body	Body Control Module																																																												
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Tahoe	Body	Passenger Presence Module																																																												
C	2016	Tahoe	Body	Instrument Cluster																																																												
C	2016	Tahoe	Body	Radio Controls																																																												
C	2016	Tahoe	Body	HVAC Controls																																																												
C	2016	Tahoe	Body	Radio																																																												
C	2016	Tahoe	Body	Amplifier																																																												
C	2016	Tahoe	Body	Media Disc Player																																																												
C	2016	Tahoe	Body	Human Machine Interface Control Module																																																												
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																												
C	2016	Tahoe	Body	HVAC Control Module																																																												
C	2016	Tahoe	Body	Liftgate Control Module																																																												
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																												
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																												
C	2016	Tahoe	Body	Keyless Entry Control Module																																																												
C	2016	Tahoe	Body	Assist Step Control Module																																																												
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																																												
C	2016	Tahoe	Body	Parking Assist Control Module																																																												
C	2016	Tahoe	Body	Frontview Camera Module																																																												
C	2016	Tahoe	Body	Steering Column Lock Control Module																																																												
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																												
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																							V																					
E	2004	ALL	Chassis	Electronic Brake Control Module																																																												
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																												
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																												
E	2006	ALL	Chassis	Electronic Brake Control Module																																																												
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																												
E	2007	ALL	Chassis	Electronic Brake Control Module																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																													
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																													
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																													
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																													
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																													
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																													
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																													
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																													
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																													
G	2004	Express/Savana	Chassis	VSES																																																													
G	2004	Express/Savana	Body	Body Control Module																																																													
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																													
G	2004	Express/Savana	Body	OnStar																																																													
G	2004	Express/Savana	Body	Base Radio																																																													
G	2004	Express/Savana	Body	Uplevel Radio																																																													
G	2004	Express/Savana	Body	Remote Function Actuation																																																													
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																													
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																													
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																													
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																													
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																													
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																													
G	2004	Express Access/Savana Pro	Chassis	VSES																																																													
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																													
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																													
G	2004	Express Access/Savana Pro	Body	OnStar																																																													
G	2004	Express Access/Savana Pro	Body	Base Radio																																																													
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																													
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																													
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																													
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																													
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																													
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																													
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																														
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																														
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																														
G	2005	Express/Savana	Chassis	VSES																																																														
G	2005	Express/Savana	Body	Body Control Module																																																														
G	2005	Express/Savana	Body	Instrument Panel Cluster																																							V																						
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																														
G	2005	Express/Savana	Body	Base Radio																																																														
G	2005	Express/Savana	Body	Uplevel Radio																																																														
G	2005	Express/Savana	Body	Remote Function Actuation																																																														
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																														
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																														
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																														
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																														
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																														
G	2005	Express Access/Savana Pro	Chassis	VSES																																																														
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																														
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																							V																						
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																														
G	2005	Express Access/Savana Pro	Body	Base Radio																																																														
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																														
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																														
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																														
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																														
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																														
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																														
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																												
G	2006	Express/Savana	Chassis	VSES																																																												
G	2006	Express/Savana	Body	Body Control Module																																																												
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																												
G	2006	Express/Savana	Body	Passenger Presence System																																																												
G	2006	Express/Savana	Body	Base Radio																																																												
G	2006	Express/Savana	Body	Uplevel Radio																																																												
G	2006	Express/Savana	Body	Remote Function Actuation																																																												
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
G	2006	Express Access/Savana Pro	Chassis	VSES																																																												
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2006	Express Access/Savana Pro	Body	Base Radio																																																												
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																												
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																														
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																															
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																															
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																															
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																															
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																															
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																															
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																															
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																															
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																															
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																															
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																															
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																															
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																															
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																															
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																															
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																															
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																															
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																															
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																															
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																															
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																															
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																															
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																															
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																															
G	2007	Express/Savana	Body	Body Control Module																																																															
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																															
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																															
G	2007	Express/Savana	Body	Passenger Presence System																																																															
G	2007	Express/Savana	Body	Base Radio																																																															
G	2007	Express/Savana	Body	Uplevel Radio																																																															
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																															
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																															
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																															
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																															
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																															
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																															
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																															
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																															
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																															
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																															
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																															
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																															
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																															
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																															
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																															
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																												
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2007	Express Access/Savana Pro	Body	Radio																																																												
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2008	Express/Savana	Body	Body Control Module																																																												
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2008	Express/Savana	Body	Passenger Presence System																																																												
G	2008	Express/Savana	Body	Radio																																																												
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2008	Express/Savana	Body	Rollover Sensor																																																												
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2008	Express/Savana	Body	Theft Deterrent Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																														
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																													
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																													
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																													
G	2008	Express Access/Savana Pro	Body	Radio																																																													
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																													
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																													
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																													
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																													
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2009	Express/Savana	Body	Body Control Module																																																													
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2009	Express/Savana	Body	Passenger Presence System																																																													
G	2009	Express/Savana	Body	Radio																																																													
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
G	2009	Express/Savana	Body	Rollover Sensor																																																													
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
G	2009	Express/Savana	Body	Theft Deterrent Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2009	Express Access/Savana Pro	Body	Radio																																																												
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																															
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																											
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express/Savana	Body	Body Control Module																																																												
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2010	Express/Savana	Body	Passenger Presence System																																																												
G	2010	Express/Savana	Body	Radio																																																												
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2010	Express/Savana	Body	Rollover Sensor																																																												
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2010	Express/Savana	Body	Theft Deterrent Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																														
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																													
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																													
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																													
G	2010	Express Access/Savana Pro	Body	Radio																																																													
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																													
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																													
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																													
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																													
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																													
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																															
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																											
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																													
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2011	Express/Savana	Body	Body Control Module																																																													
G	2011	Express/Savana	Body	Digital Radio Receiver																																																													
G	2011	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2011	Express/Savana	Body	Passenger Presence System																																																													
G	2011	Express/Savana	Body	Radio																																																													
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
G	2011	Express/Savana	Body	Rollover Sensor																																																													
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
G	2011	Express/Savana	Body	Theft Deterrent Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																													
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																														
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																										
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2011	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																											
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2011	Express Access/Savana Pro	Body	Radio																																																											
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																														
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																										
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2012	Express/Savana	Body	Body Control Module																																																											
G	2012	Express/Savana	Body	Digital Radio Receiver																																																											
G	2012	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2012	Express/Savana	Body	Passenger Presence System																																																											
G	2012	Express/Savana	Body	Radio																																																											
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2012	Express/Savana	Body	Rollover Sensor																																																											
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2012	Express/Savana	Body	Theft Deterrent Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																											
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2012	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2012	Express Access/Savana Pro	Body	Radio																																																												
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V					V							V																																							
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																											
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2013	Express/Savana	Body	Body Control Module																																																												
G	2013	Express/Savana	Body	Digital Radio Receiver																																																												
G	2013	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2013	Express/Savana	Body	Navigation Radio																																																												
G	2013	Express/Savana	Body	Park Assist Module																																																												
G	2013	Express/Savana	Body	Passenger Presence System																																																												
G	2013	Express/Savana	Body	Radio																																																												
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2013	Express/Savana	Body	Rollover Sensor																																																												
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2013	Express/Savana	Body	Theft Deterrent Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																														
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																														
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																															
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V					V							V																																									
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																												
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																														
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																														
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																														
G	2013	Express Access/Savana Pro	Body	Body Control Module																																																														
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																														
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																														
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																																														
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																																														
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																														
G	2013	Express Access/Savana Pro	Body	Radio																																																														
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																														
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																														
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																														
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																															
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																								V	V	V																			
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																															
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																															
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																															
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																															
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																								V	V	V																			
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																															
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																															
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																															
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																															
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module							V																		V	V	V	V	V	V	V	V																															
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																															
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																															
G	2014	Express	Chassis	Electronic Brake Control Module																																																															
G	2014	Express	Body	Body Control Module																																																															
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
G	2014	Express	Body	Passenger Presence Module																																																															
G	2014	Express	Body	Rollover Sensor Module																																																															
G	2014	Express	Body	Instrument Cluster																																																															
G	2014	Express	Body	Chime Alarm Control Module																																																															
G	2014	Express	Body	Base Radio																																																															
G	2014	Express	Body	Navigation Radio																																																															
G	2014	Express	Body	Uplevel Radio																																																															
G	2014	Express	Body	Digital Radio Receiver Control Module																																																															
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																															
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																															
G	2014	Express	Body	Auxiliary Heater Control Module																																																															
G	2014	Express	Body	Remote Control Door Lock Receiver																																																															
G	2014	Express	Body	Parking Assist Control Module																																																															
G	2014	Express	Body	Theft Deterrent Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																											
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																							V	V	V																	
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																											
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																											
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																											
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																							V	V	V																	
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																													
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
G	2014	Savana	Chassis	Electronic Brake Control Module																																																											
G	2014	Savana	Body	Body Control Module																																																										
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
G	2014	Savana	Body	Passenger Presence Module																																																											
G	2014	Savana	Body	Rollover Sensor Module																																																											
G	2014	Savana	Body	Instrument Cluster																																																										
G	2014	Savana	Body	Chime Alarm Control Module																																																											
G	2014	Savana	Body	Base Radio																																																										
G	2014	Savana	Body	Navigation Radio																																																										
G	2014	Savana	Body	Uplevel Radio																																																										
G	2014	Savana	Body	Digital Radio Receiver Control Module																																																											
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											
G	2014	Savana	Body	Auxiliary Heater Control Module																																																											
G	2014	Savana	Body	Remote Control Door Lock Receiver																																																											
G	2014	Savana	Body	Parking Assist Control Module																																																											
G	2014	Savana	Body	Theft Deterrent Module																																																											
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																													
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
G	2015	Express	Chassis	Electronic Brake Control Module																																																											
G	2015	Express	Body	Body Control Module																																																										
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
G	2015	Express	Body	Rollover Sensor Module																																																											
G	2015	Express	Body	Instrument Cluster																																																										
G	2015	Express	Body	Digital Radio Receiver Control Module																																																											
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																											
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																											
G	2015	Express	Body	Auxiliary Heater Control Module																																																											
G	2015	Express	Body	Remote Control Door Lock Receiver																																																											
G	2015	Express	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2015	Express	Body	Theft Deterrent Module																																																											
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																														
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
G	2015	Savana	Chassis	Electronic Brake Control Module																																																												
G	2015	Savana	Body	Body Control Module																																																											
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2015	Savana	Body	Rollover Sensor Module																																																												
G	2015	Savana	Body	Instrument Cluster																																																												
G	2015	Savana	Body	Digital Radio Receiver Control Module																																																												
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																												
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																												
G	2015	Savana	Body	Auxiliary Heater Control Module																																																												
G	2015	Savana	Body	Remote Control Door Lock Receiver																																																												
G	2015	Savana	Body	Parking Assist Control Module																																																											
G	2015	Savana	Body	Theft Deterrent Module																																																												
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																						V																																					
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																														
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
G	2016	Express	Chassis	Electronic Brake Control Module																																																												
G	2016	Express	Body	Body Control Module																																																											
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
G	2016	Express	Body	Instrument Cluster																																																												
G	2016	Express	Body	Chime Alarm Control Module																																																												
G	2016	Express	Body	Base Radio																																																											
G	2016	Express	Body	Navigation Radio																																																											
G	2016	Express	Body	Uplevel Radio																																																											
G	2016	Express	Body	Digital Radio Receiver Control Module																																																												
G	2016	Express	Body	Telematics Communication Interface Control Module																																																												
G	2016	Express	Body	Auxiliary Heater Control Module																																																												
G	2016	Express	Body	Remote Control Door Lock Receiver																																																												
G	2016	Express	Body	Parking Assist Control Module																																																												
G	2016	Express	Body	Theft Deterrent Module																																																												
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																						V																																					
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																												
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
G	2016	Savana	Chassis	Electronic Brake Control Module																																																										
G	2016	Savana	Body	Body Control Module																																																									
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
G	2016	Savana	Body	Instrument Cluster																																																										
G	2016	Savana	Body	Chime Alarm Control Module																																																										
G	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
G	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
G	2016	Savana	Body	Auxiliary Heater Control Module																																																										
G	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
G	2016	Savana	Body	Parking Assist Control Module																																																										
G	2016	Savana	Body	Theft Deterrent Module																																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2004	Express/Savana	Chassis	VSES																																																										
H	2004	Express/Savana	Body	Body Control Module																																																										
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2004	Express/Savana	Body	OnStar																																																										
H	2004	Express/Savana	Body	Base Radio																																																										
H	2004	Express/Savana	Body	Uplevel Radio																																																										
H	2004	Express/Savana	Body	Remote Function Actuation																																																										
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2004	Express Access/Savana Pro	Chassis	VSES																																																										
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2004	Express Access/Savana Pro	Body	OnStar																																																										
H	2004	Express Access/Savana Pro	Body	Base Radio																																																										
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2005	Express/Savana	Chassis	VSES																																																										
H	2005	Express/Savana	Body	Body Control Module																																																										
H	2005	Express/Savana	Body	Instrument Panel Cluster																																						V																					
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2005	Express/Savana	Body	Base Radio																																																										
H	2005	Express/Savana	Body	Uplevel Radio																																																										
H	2005	Express/Savana	Body	Remote Function Actuation																																																										
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2005	Express Access/Savana Pro	Chassis	VSES																																																												
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																							V																				
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2005	Express Access/Savana Pro	Body	Base Radio																																																												
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																												
H	2006	Express/Savana	Chassis	VSES																																																												
H	2006	Express/Savana	Body	Body Control Module																																																												
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																												
H	2006	Express/Savana	Body	Passenger Presence System																																																												
H	2006	Express/Savana	Body	Base Radio																																																												
H	2006	Express/Savana	Body	Uplevel Radio																																																												
H	2006	Express/Savana	Body	Remote Function Actuation																																																												
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2006	Express Access/Savana Pro	Chassis	VSES																																																												
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2006	Express Access/Savana Pro	Body	Base Radio																																																												
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express/Savana	Body	Body Control Module																																																										
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2007	Express/Savana	Body	Passenger Presence System																																																										
H	2007	Express/Savana	Body	Base Radio																																																										
H	2007	Express/Savana	Body	Uplevel Radio																																																										
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2007	Express Access/Savana Pro	Body	Base Radio																																																										
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express/Savana	Body	Body Control Module																																																										
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2008	Express/Savana	Body	Passenger Presence System																																																										
H	2008	Express/Savana	Body	Radio																																																										
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express/Savana	Body	Rollover Sensor																																																										
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express/Savana	Body	Theft Deterrent Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2008	Express Access/Savana Pro	Body	Radio																																																												
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2009	Express/Savana	Body	Body Control Module																																																												
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2009	Express/Savana	Body	Passenger Presence System																																																												
H	2009	Express/Savana	Body	Radio																																																												
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2009	Express/Savana	Body	Rollover Sensor																																																												
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2009	Express/Savana	Body	Theft Deterrent Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2009	Express Access/Savana Pro	Body	Radio																																																												
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																															
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																															
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																																
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																																
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																																
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																																
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																																
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																																
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																																
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																																
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																																
H	2010	Express/Savana	Body	Body Control Module																																																																
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																																
H	2010	Express/Savana	Body	Passenger Presence System																																																																
H	2010	Express/Savana	Body	Radio																																																																
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																																
H	2010	Express/Savana	Body	Rollover Sensor																																																																
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																																
H	2010	Express/Savana	Body	Theft Deterrent Module																																																																
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																																
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																																
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																																
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																																
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																																
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																																
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																																
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																																
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																																
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																																
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																																
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																																
H	2010	Express Access/Savana Pro	Body	Radio																																																																
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																																
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																																
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																																
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																																
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																																
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																																
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																																
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																																
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																																
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																																
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																																
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																																
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																																
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																																
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																																
H	2011	Express/Savana	Body	Body Control Module																																																																
H	2011	Express/Savana	Body	Digital Radio Receiver																																																																
H	2011	Express/Savana	Body	Instrument Panel Cluster																																																																
H	2011	Express/Savana	Body	Passenger Presence System																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2011	Express/Savana	Body	Radio																																																												
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2011	Express/Savana	Body	Rollover Sensor																																																												
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2011	Express/Savana	Body	Theft Deterrent Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2011	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2011	Express Access/Savana Pro	Body	Radio																																																												
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2012	Express/Savana	Body	Body Control Module																																																												
H	2012	Express/Savana	Body	Digital Radio Receiver																																																												
H	2012	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2012	Express/Savana	Body	Passenger Presence System																																																												
H	2012	Express/Savana	Body	Radio																																																												
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2012	Express/Savana	Body	Rollover Sensor																																																												
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2012	Express/Savana	Body	Theft Deterrent Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2012	Express Access/Savana Pro	Body	Radio																																																										
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2013	Express/Savana	Body	Body Control Module																																																										
H	2013	Express/Savana	Body	Digital Radio Receiver																																																										
H	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2013	Express/Savana	Body	Navigation Radio																																																										
H	2013	Express/Savana	Body	Park Assist Module																																																										
H	2013	Express/Savana	Body	Passenger Presence System																																																										
H	2013	Express/Savana	Body	Radio																																																										
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2013	Express/Savana	Body	Rollover Sensor																																																										
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2013	Express/Savana	Body	Theft Deterrent Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2013	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																																												
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2013	Express Access/Savana Pro	Body	Radio																																																												
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																								V	V	V																	
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																													
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
H	2014	Express	Chassis	Electronic Brake Control Module																																																												
H	2014	Express	Body	Body Control Module																																																												
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2014	Express	Body	Passenger Presence Module																																																												
H	2014	Express	Body	Rollover Sensor Module																																																												
H	2014	Express	Body	Instrument Cluster																																																												
H	2014	Express	Body	Chime Alarm Control Module																																																												
H	2014	Express	Body	Base Radio																																																												
H	2014	Express	Body	Navigation Radio																																																												
H	2014	Express	Body	Uplevel Radio																																																												
H	2014	Express	Body	Digital Radio Receiver Control Module																																																												
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																																												
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																																												
H	2014	Express	Body	Auxiliary Heater Control Module																																																												
H	2014	Express	Body	Remote Control Door Lock Receiver																																																												
H	2014	Express	Body	Parking Assist Control Module																																																												
H	2014	Express	Body	Theft Deterrent Module																																																												
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																								V	V	V																	
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																													
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
H	2014	Savana	Chassis	Electronic Brake Control Module																																																														
H	2014	Savana	Body	Body Control Module																																																													
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
H	2014	Savana	Body	Passenger Presence Module																																																														
H	2014	Savana	Body	Rollover Sensor Module																																																														
H	2014	Savana	Body	Instrument Cluster																																																														
H	2014	Savana	Body	Chime Alarm Control Module																																																														
H	2014	Savana	Body	Base Radio																																																														
H	2014	Savana	Body	Navigation Radio																																																														
H	2014	Savana	Body	Uplevel Radio																																																														
H	2014	Savana	Body	Digital Radio Receiver Control Module																																																														
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																														
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																														
H	2014	Savana	Body	Auxiliary Heater Control Module																																																														
H	2014	Savana	Body	Remote Control Door Lock Receiver																																																														
H	2014	Savana	Body	Parking Assist Control Module																																																														
H	2014	Savana	Body	Theft Deterrent Module																																																														
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																														
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																														
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																														
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																																														
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																														
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																															
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																														
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																														
H	2015	Express	Chassis	Electronic Brake Control Module																																																														
H	2015	Express	Body	Body Control Module																																																														
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
H	2015	Express	Body	Rollover Sensor Module																																																														
H	2015	Express	Body	Instrument Cluster																																																														
H	2015	Express	Body	Digital Radio Receiver Control Module																																																														
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																																														
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																																														
H	2015	Express	Body	Auxiliary Heater Control Module																																																														
H	2015	Express	Body	Remote Control Door Lock Receiver																																																														
H	2015	Express	Body	Parking Assist Control Module																																																														
H	2015	Express	Body	Theft Deterrent Module																																																														
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																														
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																														
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																														
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																														
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																														
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																															
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																														
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																														
H	2015	Savana	Chassis	Electronic Brake Control Module																																																														
H	2015	Savana	Body	Body Control Module																																																														
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2015	Savana	Body	Rollover Sensor Module																																																												
H	2015	Savana	Body	Instrument Cluster																																																												
H	2015	Savana	Body	Digital Radio Receiver Control Module																																																												
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																												
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																												
H	2015	Savana	Body	Auxiliary Heater Control Module																																																												
H	2015	Savana	Body	Remote Control Door Lock Receiver																																																												
H	2015	Savana	Body	Parking Assist Control Module																																																												
H	2015	Savana	Body	Theft Deterrent Module																																																												
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																						V																																					
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																													
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
H	2016	Express	Chassis	Electronic Brake Control Module																																																												
H	2016	Express	Body	Body Control Module																																																											
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2016	Express	Body	Instrument Cluster																																																												
H	2016	Express	Body	Chime Alarm Control Module																																																												
H	2016	Express	Body	Base Radio																																																											
H	2016	Express	Body	Navigation Radio																																																											
H	2016	Express	Body	Uplevel Radio																																																											
H	2016	Express	Body	Digital Radio Receiver Control Module																																																												
H	2016	Express	Body	Telematics Communication Interface Control Module																																																												
H	2016	Express	Body	Auxiliary Heater Control Module																																																												
H	2016	Express	Body	Remote Control Door Lock Receiver																																																												
H	2016	Express	Body	Parking Assist Control Module																																																												
H	2016	Express	Body	Theft Deterrent Module																																																												
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																						V																																					
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																													
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
H	2016	Savana	Chassis	Electronic Brake Control Module																																																												
H	2016	Savana	Body	Body Control Module																																																											
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
H	2016	Savana	Body	Instrument Cluster																																																												
H	2016	Savana	Body	Chime Alarm Control Module																																																												
H	2016	Savana	Body	Digital Radio Receiver Control Module																																																												
H	2016	Savana	Body	Telematics Communication Interface Control Module																																																												
H	2016	Savana	Body	Auxiliary Heater Control Module																																																												
H	2016	Savana	Body	Remote Control Door Lock Receiver																																																												
H	2016	Savana	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2016	Savana	Body	Theft Deterrent Module																																																												
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																												
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																						V																						
J	2004	ALL	Chassis	Electronic Brake Control Module																																																												
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																												
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																																												
J	2007	ALL	Chassis	Electronic Brake Control Module																																																												
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																												
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																												
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																												
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																												
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																												
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																																												
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																																												
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																												
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																												
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																																												
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																																												
J	2013	Tracker	Chassis	Electronic Brake Control Module																																																												
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																																												
J	2013	Tracker	Chassis	Power Steering Control Module																																																												
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2013	Tracker	Body	Body Control Module																																																												
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
J	2013	Tracker	Body	Passenger Presence Module																																																												
J	2013	Tracker	Body	Instrument Cluster																																																												
J	2013	Tracker	Body	Radio																																																												
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																																												
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																																												
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																												
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																																												
J	2013	Tracker	Body	Front Seat Heating Control Module																																																												
J	2013	Tracker	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
J	2013	Tracker	Body	Frontview Camera Module																																																														
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																															
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																															
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																															
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																															
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																															
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																															
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																															
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																															
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																															
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																																															
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																															
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																															
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																															
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																															
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																															
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																															
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																															
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																															
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																															
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																																															
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																															
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																															
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																															
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																															
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																															
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																															
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																															
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																															
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																															
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																																															
J	2013	Trax	Chassis	Electronic Brake Control Module																																																															
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																																															
J	2013	Trax	Chassis	Power Steering Control Module																																																															
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																																															
J	2013	Trax	Body	Body Control Module																																																															
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
J	2013	Trax	Body	Passenger Presence Module																																																															
J	2013	Trax	Body	Instrument Cluster																																																															
J	2013	Trax	Body	Radio																																																															
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																																															
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																																															
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																																															
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																															
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																																															
J	2013	Trax	Body	Front Seat Heating Control Module																																																															
J	2013	Trax	Body	Parking Assist Control Module																																																															
J	2013	Trax	Body	Frontview Camera Module																																																															
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																															
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																															
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																												
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																													
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																																													
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																																													
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																																													
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																													
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																													
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																													
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																													
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																													
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																													
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																													
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																													
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																													
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																													
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																													
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																													
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																													
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																													
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																													
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																																													
J	2014	Tracker	Chassis	Electronic Brake Control Module																																																													
J	2014	Tracker	Chassis	Power Steering Control Module																																																													
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2014	Tracker	Body	Body Control Module																																																													
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2014	Tracker	Body	Passenger Presence Module																																																													
J	2014	Tracker	Body	Instrument Cluster																																																													
J	2014	Tracker	Body	Radio																																																												
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																																													
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																																													
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																																													
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																																													
J	2014	Tracker	Body	Front Seat Heating Control Module																																																													
J	2014	Tracker	Body	Parking Assist Control Module																																																													
J	2014	Tracker	Body	Frontview Camera Module																																																													
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																													
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																													
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																													
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																													
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																																											
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																																											
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																											
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																											
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
J	2014	Trax	Powertrain	Fuel Injector Control Module																																																												
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																																												
J	2014	Trax	Chassis	Electronic Brake Control Module																																																												
J	2014	Trax	Chassis	Power Steering Control Module																																																												
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																																												
J	2014	Trax	Body	Body Control Module																																																											
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2014	Trax	Body	Passenger Presence Module																																																											
J	2014	Trax	Body	Instrument Cluster																																																											
J	2014	Trax	Body	Radio																																																											
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																																											
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																																											
J	2014	Trax	Body	Front Seat Heating Control Module																																																											
J	2014	Trax	Body	Parking Assist Control Module																																																											
J	2014	Trax	Body	Frontview Camera Module																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																											
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																											
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																											
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																											
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																																											
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																																											
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																																											
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																											
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																											
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15:Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																																										
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																																										
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																																										
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																										
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Tracker	Chassis	Electronic Brake Control Module																																																										
J	2015	Tracker	Chassis	Power Steering Control Module																																																										
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Tracker	Body	Body Control Module																																																										
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Tracker	Body	Instrument Cluster																																																										
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																																										
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																																										
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																																										
J	2015	Tracker	Body	Front Seat Heating Control Module																																																										
J	2015	Tracker	Body	Parking Assist Control Module																																																										
J	2015	Tracker	Body	Frontview Camera Module																																																										
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																																										
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																										
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																										
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																										
J	2015	Trax	Powertrain	Fuel Injector Control Module																																																										
J	2015	Trax	Powertrain	Chassis Control Module																																																										
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																																										
J	2015	Trax	Chassis	Electronic Brake Control Module																																																										
J	2015	Trax	Chassis	Power Steering Control Module																																																										
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																																										
J	2015	Trax	Body	Body Control Module																																																										
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
J	2015	Trax	Body	Passenger Presence Module																																																										
J	2015	Trax	Body	Instrument Cluster																																																										
J	2015	Trax	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																										
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																																											
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																																											
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																																											
J	2015	Trax	Body	Seat Memory Control Module																																																											
J	2015	Trax	Body	Front Seat Heating Control Module																																																											
J	2015	Trax	Body	Right Side Object Detection Control Module																																																											
J	2015	Trax	Body	Left Side Object Detection Control Module																																																											
J	2015	Trax	Body	Parking Assist Control Module																																																											
J	2015	Trax	Body	Frontview Camera Module																																																											
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																											
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																											
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																																											
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																																											
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																																											
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																																											
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																											
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																																											
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																																											
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																																											
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																																											
J	2016	Tracker	Chassis	Electronic Brake Control Module																																																											
J	2016	Tracker	Chassis	Power Steering Control Module																																																											
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																																											
J	2016	Tracker	Body	Body Control Module																																																											
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
J	2016	Tracker	Body	Instrument Cluster																																																											
J	2016	Tracker	Body	Trailer Interface Control Module																																																											
J	2016	Tracker	Body	Radio																																																											
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																																											
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																																											
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																																											
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																																											
J	2016	Tracker	Body	Front Seat Heating Control Module																																																											
J	2016	Tracker	Body	Parking Assist Control Module																																																											
J	2016	Tracker	Body	Frontview Camera Module																																																											
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																																											
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																																											
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																																											
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																																											
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																																											
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																											
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																											
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																																											
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																																											
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																																											
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																																												
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																																													
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																													
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																													
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																																													
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																																													
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																																													
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
J	2016	Trax	Powertrain	Fuel Injector Control Module																																																													
J	2016	Trax	Powertrain	Chassis Control Module																																																													
J	2016	Trax	Chassis	Electronic Brake Control Module																																																													
J	2016	Trax	Chassis	Power Steering Control Module																																																													
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																																													
J	2016	Trax	Body	Body Control Module																																																													
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
J	2016	Trax	Body	Passenger Presence Module																																																													
J	2016	Trax	Body	Instrument Cluster																																																													
J	2016	Trax	Body	Trailer Interface Control Module																																																													
J	2016	Trax	Body	Radio																																																												
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																																													
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																																													
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																																													
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																																													
J	2016	Trax	Body	Seat Memory Control Module																																																													
J	2016	Trax	Body	Front Seat Heating Control Module																																																													
J	2016	Trax	Body	Right Side Object Detection Control Module																																																													
J	2016	Trax	Body	Left Side Object Detection Control Module																																																													
J	2016	Trax	Body	Parking Assist Control Module																																																													
J	2016	Trax	Body	Frontview Camera Module																																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																												V																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																												V																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																												V																	
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																												V																	
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																													
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																													
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																												V																	
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																													
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																													
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																												V																	
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																												V																	

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																															V
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																															V
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																															V
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																															V
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																																V
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																																V
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																															V
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																															V
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																															V
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																															V
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																															
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																															
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																															
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																															
K	2004	ALL	Chassis	ESC																																																															
K	2004	ALL	Chassis	Rear Wheel Steering																																																															
K	2004	ALL	Chassis	Tire Pressure Monitor																																																															
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																															
K	2004	ALL	Chassis	VSES																																																															
K	2004	ALL	Body	Amplifier (Bose)																																																															
K	2004	ALL	Body	Body Control Module																																																															
K	2004	ALL	Body	CD Changer																																																															
K	2004	ALL	Body	Chime																																																															
K	2004	ALL	Body	Driver Door Module																																																															
K	2004	ALL	Body	Driver Seat Module																																																															
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																															
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																															
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																															
K	2004	ALL	Body	Instrument Panel Cluster																																																															
K	2004	ALL	Body	OnStar																																																															
K	2004	ALL	Body	Passenger Door Module																																																															
K	2004	ALL	Body	Passenger Presence System																																																															
K	2004	ALL	Body	Radio Base																																																															
K	2004	ALL	Body	Radio Uplevel																																																															
K	2004	ALL	Body	Radio Navigation																																																															
K	2004	ALL	Body	Rear Aux. Climate Module																																																															
K	2004	ALL	Body	Rear HVAC																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2004	ALL	Body	Rear Seat Audio																																																														
K	2004	ALL	Body	Rear Seat Entertainment																																																														
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2004	ALL	Body	Vehicle Theft Deterrent																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																															V
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																														V
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																															V
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																															V
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																															V
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																															
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																															V
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																															
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																															
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																															V
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																															V
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																															V
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																																V
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																																V
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																															
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																															
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																															
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																																V
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																																	V
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																																	V
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																															
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																															
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																															V
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																															
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																															
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																															
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																															V
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																																V
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																													
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																													
K	2005	ALL	Chassis	ESC																																																													
K	2005	ALL	Chassis	Rear Wheel Steering																																																													
K	2005	ALL	Chassis	Tire Pressure Monitor																																																													
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																													
K	2005	ALL	Chassis	VSES																																																													
K	2005	ALL	Body	Amplifier (Bose)																																																													
K	2005	ALL	Body	Body Control Module																																																													
K	2005	ALL	Body	CD Changer																																																													
K	2005	ALL	Body	Chime																																																													
K	2005	ALL	Body	Disc Player and Video Display																																																													
K	2005	ALL	Body	Driver Door Module																																																													
K	2005	ALL	Body	Driver Seat Module																																																													
K	2005	ALL	Body	Generator Battery Control Module																																																													
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																													
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																													
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																													
K	2005	ALL	Body	Instrument Panel Cluster																																																													
K	2005	ALL	Body	Passenger Door Module																																																													
K	2005	ALL	Body	Passenger Presence System																																																													
K	2005	ALL	Body	Base Radio																																																													
K	2005	ALL	Body	Uplevel Radio																																																													
K	2005	ALL	Body	Navigation Radio																																																													
K	2005	ALL	Body	Rear Aux. Climate Module																																																													
K	2005	ALL	Body	Rear HVAC																																																													
K	2005	ALL	Body	Rear Seat Audio																																																													
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																													
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																													
K	2005	ALL	Body	Vehicle Theft Deterrent																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																													
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																													
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																													
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																													
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																													
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																													
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																									V															
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																									V															
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																									V															
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																							
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																							
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																									V															
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																									V															
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																									V															
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																							
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																							
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																							
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																									V															
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																									V															
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																									V															
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																							
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																							
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																									V															
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																									V															
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																							
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																							
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																							
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																									V															
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																							
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																							
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																							
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																									V															
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																							
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																							
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																							
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																									V															
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																									V															
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																							
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																							
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																							
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																							
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																							
K	2006	ALL	Chassis	ESC																																																							
K	2006	ALL	Chassis	Tire Pressure Monitor																																																							
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																							
K	2006	ALL	Chassis	VSES																																																							
K	2006	ALL	Body	Amplifier (Bose)																																																							
K	2006	ALL	Body	Body Control Module																																																							
K	2006	ALL	Body	CD Changer																																																							
K	2006	ALL	Body	Chime																																																							
K	2006	ALL	Body	Disc Player and Video Display																																																							
K	2006	ALL	Body	Driver Door Module																																																							
K	2006	ALL	Body	Driver Seat Module																																																							
K	2006	ALL	Body	Generator Battery Control Module																																																							
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																							

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2006	ALL	Body	Instrument Panel Cluster																																																												
K	2006	ALL	Body	Passenger Door Module																																																												
K	2006	ALL	Body	Passenger Presence System																																																												
K	2006	ALL	Body	Base Radio																																																												
K	2006	ALL	Body	Uplevel Radio																																																												
K	2006	ALL	Body	Navigation Radio																																																												
K	2006	ALL	Body	Rear Aux. Climate Module																																																												
K	2006	ALL	Body	Rear HVAC																																																												
K	2006	ALL	Body	Rear Seat Audio																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2006	ALL	Body	Vehicle Theft Deterrent																																																												
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Avalanche	Chassis	Electronic Suspension Control																																																												
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																																												
K	2007	Avalanche	Body	Amplifier (Bose)																																																												
K	2007	Avalanche	Body	Assist Step Controller																																																												
K	2007	Avalanche	Body	Body Control Module																																																												
K	2007	Avalanche	Body	Body Control Module (aux.)																																																												
K	2007	Avalanche	Body	Digital Radio Receiver																																																												
K	2007	Avalanche	Body	Driver Door Switch																																																												
K	2007	Avalanche	Body	HVAC Control Module Auto																																																												
K	2007	Avalanche	Body	HVAC Control Module Manual																																																												
K	2007	Avalanche	Body	Instrument Panel Cluster																																																												
K	2007	Avalanche	Body	Memory Seat Module																																																												
K	2007	Avalanche	Body	Park Assist Module																																																												
K	2007	Avalanche	Body	Passenger Door Switch																																																												
K	2007	Avalanche	Body	Passenger Presence System																																																												
K	2007	Avalanche	Body	Radio																																																												
K	2007	Avalanche	Body	Rear Heated Seat Module																																																												
K	2007	Avalanche	Body	Rear HVAC/RSA																																																												
K	2007	Avalanche	Body	Rollover Sensor																																																												
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																																																												
K	2007	Avalanche	Body	Theft Deterrent Module																																																												
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Suburban	Chassis	Electronic Suspension Control																																																												
K	2007	Suburban	Chassis	Trailer Brake Control Module																																																												
K	2007	Suburban	Body	Amplifier (Bose)																																																												
K	2007	Suburban	Body	Assist Step Controller																																																												
K	2007	Suburban	Body	Body Control Module																																																												
K	2007	Suburban	Body	Body Control Module (aux.)																																																												
K	2007	Suburban	Body	Digital Radio Receiver																																																												
K	2007	Suburban	Body	Driver Door Switch																																																												
K	2007	Suburban	Body	HVAC Control Module Auto																																																												
K	2007	Suburban	Body	HVAC Control Module Manual																																																												
K	2007	Suburban	Body	Instrument Panel Cluster																																																												
K	2007	Suburban	Body	Lift Gate Module																																																												
K	2007	Suburban	Body	Memory Seat Module																																																												
K	2007	Suburban	Body	Park Assist Module																																																												
K	2007	Suburban	Body	Passenger Door Switch																																																												
K	2007	Suburban	Body	Passenger Presence System																																																												
K	2007	Suburban	Body	Radio																																																												
K	2007	Suburban	Body	Rear Heated Seat Module																																																												
K	2007	Suburban	Body	Rear HVAC/RSA																																																												
K	2007	Suburban	Body	Rollover Sensor																																																												
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2007	Suburban	Body	Theft Deterrent Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																											
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																											
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2007	Silverado	Chassis	Electronic Suspension Control																																																											
K	2007	Silverado	Chassis	Trailer Brake Control Module																																																											
K	2007	Silverado	Body	Amplifier (Bose)																																																											
K	2007	Silverado	Body	Body Control Module																																																											
K	2007	Silverado	Body	Body Control Module (aux.)																																																											
K	2007	Silverado	Body	Digital Radio Receiver																																																											
K	2007	Silverado	Body	Driver Door Switch																																																											
K	2007	Silverado	Body	HVAC Control Module Auto																																																											
K	2007	Silverado	Body	HVAC Control Module Manual																																																											
K	2007	Silverado	Body	Instrument Panel Cluster																																																											
K	2007	Silverado	Body	Memory Seat Module																																																											
K	2007	Silverado	Body	Park Assist Module																																																											
K	2007	Silverado	Body	Passenger Door Switch																																																											
K	2007	Silverado	Body	Passenger Presence System																																																											
K	2007	Silverado	Body	Radio																																																											
K	2007	Silverado	Body	Rear Heated Seat Module																																																											
K	2007	Silverado	Body	Rear HVAC/RSA																																																											
K	2007	Silverado	Body	Rollover Sensor																																																											
K	2007	Silverado	Body	Supplemental Inflatable Restraint																																																											
K	2007	Silverado	Body	Theft Deterrent Module																																																											
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																											
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2007	Tahoe	Chassis	Electronic Suspension Control																																																											
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																																											
K	2007	Tahoe	Body	Amplifier (Bose)																																																											
K	2007	Tahoe	Body	Assist Step Controller																																																											
K	2007	Tahoe	Body	Body Control Module																																																											
K	2007	Tahoe	Body	Body Control Module (aux.)																																																											
K	2007	Tahoe	Body	Digital Radio Receiver																																																											
K	2007	Tahoe	Body	Driver Door Switch																																																											
K	2007	Tahoe	Body	HVAC Control Module Auto																																																											
K	2007	Tahoe	Body	HVAC Control Module Manual																																																											
K	2007	Tahoe	Body	Instrument Panel Cluster																																																											
K	2007	Tahoe	Body	Lift Gate Module																																																											
K	2007	Tahoe	Body	Memory Seat Module																																																											
K	2007	Tahoe	Body	Park Assist Module																																																											
K	2007	Tahoe	Body	Passenger Door Switch																																																											
K	2007	Tahoe	Body	Passenger Presence System																																																											
K	2007	Tahoe	Body	Radio																																																										
K	2007	Tahoe	Body	Rear Heated Seat Module																																																											
K	2007	Tahoe	Body	Rear HVAC/RSA																																																											
K	2007	Tahoe	Body	Rollover Sensor																																																											
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																																											
K	2007	Tahoe	Body	Theft Deterrent Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2008	Avalanche	Chassis	Electronic Brake Control Module																																																											
K	2008	Avalanche	Chassis	Electronic Suspension Control																																																											
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																																											
K	2008	Avalanche	Body	Amplifier (Bose)																																																											
K	2008	Avalanche	Body	Assist Step Controller																																																											
K	2008	Avalanche	Body	Body Control Module																																																											
K	2008	Avalanche	Body	Body Control Module (aux.)																																																											
K	2008	Avalanche	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2008	Avalanche	Body	Driver Door Switch																																																											
K	2008	Avalanche	Body	HVAC Control Module Auto																																																												
K	2008	Avalanche	Body	HVAC Control Module Manual																																																												
K	2008	Avalanche	Body	Instrument Panel Cluster																																																												
K	2008	Avalanche	Body	Memory Seat Module																																																												
K	2008	Avalanche	Body	Park Assist Module																																																												
K	2008	Avalanche	Body	Passenger Door Switch																																																												
K	2008	Avalanche	Body	Passenger Presence System																																																												
K	2008	Avalanche	Body	Radio																																																												
K	2008	Avalanche	Body	Rear Heated Seat Module																																																												
K	2008	Avalanche	Body	Rear HVAC/RSA																																																												
K	2008	Avalanche	Body	Rollover Sensor																																																												
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																																												
K	2008	Avalanche	Body	Theft Deterrent Module																																																												
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2008	Suburban	Chassis	EBCM Under 8600 GVW																																																												
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2008	Suburban	Chassis	Electronic Suspension Control																																																												
K	2008	Suburban	Chassis	Trailer Brake Control Module																																																												
K	2008	Suburban	Body	Amplifier (Bose)																																																												
K	2008	Suburban	Body	Assist Step Controller																																																												
K	2008	Suburban	Body	Body Control Module																																																												
K	2008	Suburban	Body	Body Control Module (aux.)																																																												
K	2008	Suburban	Body	Digital Radio Receiver																																																												
K	2008	Suburban	Body	Driver Door Switch																																																												
K	2008	Suburban	Body	HVAC Control Module Auto																																																												
K	2008	Suburban	Body	HVAC Control Module Manual																																																												
K	2008	Suburban	Body	Instrument Panel Cluster																																																												
K	2008	Suburban	Body	Lift Gate Module																																																												
K	2008	Suburban	Body	Memory Seat Module																																																												
K	2008	Suburban	Body	Park Assist Module																																																												
K	2008	Suburban	Body	Passenger Door Switch																																																												
K	2008	Suburban	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2008	Suburban	Body	Radio																																																												
K	2008	Suburban	Body	Rear Heated Seat Module																																																												
K	2008	Suburban	Body	Rear HVAC/RSA																																																												
K	2008	Suburban	Body	Rollover Sensor																																																												
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2008	Suburban	Body	Theft Deterrent Module																																																												
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2008	Silverado	Chassis	Electronic Suspension Control																																																												
K	2008	Silverado	Chassis	Trailer Brake Control Module																																																												
K	2008	Silverado	Body	Amplifier (Bose)																																																												
K	2008	Silverado	Body	Body Control Module																																																												
K	2008	Silverado	Body	Body Control Module (aux.)																																																												
K	2008	Silverado	Body	Digital Radio Receiver																																																												
K	2008	Silverado	Body	Driver Door Switch																																																												
K	2008	Silverado	Body	HVAC Control Module Auto																																																												
K	2008	Silverado	Body	HVAC Control Module Manual																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2008	Silverado	Body	Instrument Panel Cluster																																																													
K	2008	Silverado	Body	Memory Seat Module																																																														
K	2008	Silverado	Body	Park Assist Module																																																														
K	2008	Silverado	Body	Passenger Door Switch																																																														
K	2008	Silverado	Body	Passenger Presence System																																																														
K	2008	Silverado	Body	Radio																																																														
K	2008	Silverado	Body	Rear Heated Seat Module																																																														
K	2008	Silverado	Body	Rear HVAC/RSA																																																														
K	2008	Silverado	Body	Rollover Sensor																																																														
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																																														
K	2008	Silverado	Body	Theft Deterrent Module																																																														
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																														
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																														
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																														
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																														
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																														
K	2008	Tahoe	Chassis	Electronic Brake Control Module																																																														
K	2008	Tahoe	Chassis	Electronic Suspension Control																																																														
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																																														
K	2008	Tahoe	Body	Amplifier (Bose)																																																														
K	2008	Tahoe	Body	Assist Step Controller																																																														
K	2008	Tahoe	Body	Body Control Module																																																														
K	2008	Tahoe	Body	Body Control Module (aux.)																																																														
K	2008	Tahoe	Body	Digital Radio Receiver																																																														
K	2008	Tahoe	Body	Driver Door Switch																																																														
K	2008	Tahoe	Body	HVAC Control Module Auto																																																														
K	2008	Tahoe	Body	HVAC Control Module Manual																																																														
K	2008	Tahoe	Body	Instrument Panel Cluster																																																														
K	2008	Tahoe	Body	Lift Gate Module																																																														
K	2008	Tahoe	Body	Memory Seat Module																																																														
K	2008	Tahoe	Body	Park Assist Module																																																														
K	2008	Tahoe	Body	Passenger Door Switch																																																														
K	2008	Tahoe	Body	Passenger Presence System																																																														
K	2008	Tahoe	Body	Radio																																																														
K	2008	Tahoe	Body	Rear Heated Seat Module																																																														
K	2008	Tahoe	Body	Rear HVAC/RSA																																																														
K	2008	Tahoe	Body	Rollover Sensor																																																														
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																																														
K	2008	Tahoe	Body	Theft Deterrent Module																																																														
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																														
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																													
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module			V																																																										
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																													
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module				V																																																									
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																													
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																													
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																												
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
K	2008	Tahoe Hybrid	Body	Body Control Module																																																												
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																																												
K	2008	Tahoe Hybrid	Body	HVAC Control Module																																																												
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																																												
K	2008	Tahoe Hybrid	Body	Memory Seat Module																																																												
K	2008	Tahoe Hybrid	Body	Park Assist Module																																																												
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																																												
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																																												
K	2008	Tahoe Hybrid	Body	Radio																																																												
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																																												
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																																												
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																																												
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2009	Avalanche	Chassis	Electronic Brake Control Module																																																												
K	2009	Avalanche	Chassis	Electronic Suspension Control																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																																															
K	2009	Avalanche	Body	Amplifier (Bose)																																																															
K	2009	Avalanche	Body	Assist Step Controller																																																															
K	2009	Avalanche	Body	Body Control Module																																																															
K	2009	Avalanche	Body	Body Control Module (aux.)																																																															
K	2009	Avalanche	Body	Digital Radio Receiver																																																															
K	2009	Avalanche	Body	Driver Door Switch																																																															
K	2009	Avalanche	Body	HVAC Control Module Auto																																																															
K	2009	Avalanche	Body	HVAC Control Module Manual																																																															
K	2009	Avalanche	Body	Instrument Panel Cluster																																																															
K	2009	Avalanche	Body	Memory Seat Module																																																															
K	2009	Avalanche	Body	Park Assist Module																																																															
K	2009	Avalanche	Body	Passenger Door Switch																																																															
K	2009	Avalanche	Body	Passenger Presence System																																																															
K	2009	Avalanche	Body	Radio																																																															
K	2009	Avalanche	Body	Rear Heated Seat Module																																																															
K	2009	Avalanche	Body	Rear HVAC/RSA																																																															
K	2009	Avalanche	Body	Rollover Sensor																																																															
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																																															
K	2009	Avalanche	Body	Theft Deterrent Module																																																															
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																															
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																															
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																															
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																															
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																															
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																															
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																															
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																															
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																															
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																																															
K	2009	Cheyenne	Body	Amplifier (Bose)																																																															
K	2009	Cheyenne	Body	Body Control Module (aux.)																																																															
K	2009	Cheyenne	Body	Digital Radio Receiver																																																															
K	2009	Cheyenne	Body	Driver Door Switch																																																															
K	2009	Cheyenne	Body	Instrument Panel Cluster																																																															
K	2009	Cheyenne	Body	Park Assist Module																																																															
K	2009	Cheyenne	Body	Passenger Door Switch																																																															
K	2009	Cheyenne	Body	Passenger Presence System																																																															
K	2009	Cheyenne	Body	Rear Heated Seat Module																																																															
K	2009	Cheyenne	Body	Rear HVAC/RSA																																																															
K	2009	Cheyenne	Body	Rollover Sensor																																																															
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																																															
K	2009	Cheyenne	Body	Theft Deterrent Module																																																															
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																															
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Suburban	Chassis	EBCM Under 8600 GVW																																																												
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2009	Suburban	Chassis	Electronic Suspension Control																																																												
K	2009	Suburban	Chassis	Trailer Brake Control Module																																																												
K	2009	Suburban	Body	Amplifier (Bose)																																																												
K	2009	Suburban	Body	Assist Step Controller																																																												
K	2009	Suburban	Body	Body Control Module																																																												
K	2009	Suburban	Body	Body Control Module (aux.)																																																												
K	2009	Suburban	Body	Digital Radio Receiver																																																												
K	2009	Suburban	Body	Driver Door Switch																																																												
K	2009	Suburban	Body	HVAC Control Module Auto																																																												
K	2009	Suburban	Body	HVAC Control Module Manual																																																												
K	2009	Suburban	Body	Instrument Panel Cluster																																																												
K	2009	Suburban	Body	Left Side Object Detection Module																																																												
K	2009	Suburban	Body	Lift Gate Module																																																												
K	2009	Suburban	Body	Memory Seat Module																																																												
K	2009	Suburban	Body	Park Assist Module																																																												
K	2009	Suburban	Body	Passenger Door Switch																																																												
K	2009	Suburban	Body	Passenger Presence System																																																												
K	2009	Suburban	Body	Radio																																																											
K	2009	Suburban	Body	Rear Heated Seat Module																																																												
K	2009	Suburban	Body	Rear HVAC/RSA																																																												
K	2009	Suburban	Body	Right Side Object Detection Module																																																												
K	2009	Suburban	Body	Rollover Sensor																																																												
K	2009	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2009	Suburban	Body	Theft Deterrent Module																																																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15:Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																											
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																											
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																											
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																											
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic					V																																																					
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual					V																																																					
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																											
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																											
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2009	Silverado	Chassis	Electronic Suspension Control																																																											
K	2009	Silverado	Chassis	Trailer Brake Control Module																																																											
K	2009	Silverado	Body	Amplifier (Bose)																																																											
K	2009	Silverado	Body	Body Control Module																																																										
K	2009	Silverado	Body	Body Control Module (aux.)																																																											
K	2009	Silverado	Body	Digital Radio Receiver																																																											
K	2009	Silverado	Body	Driver Door Switch																																																											
K	2009	Silverado	Body	HVAC Control Module Auto																																																											
K	2009	Silverado	Body	HVAC Control Module Manual																																																											
K	2009	Silverado	Body	Instrument Panel Cluster																																																											
K	2009	Silverado	Body	Memory Seat Module																																																											
K	2009	Silverado	Body	Park Assist Module																																																											
K	2009	Silverado	Body	Passenger Door Switch																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2009	Silverado	Body	Passenger Presence System																																																															
K	2009	Silverado	Body	Radio																																																															
K	2009	Silverado	Body	Rear Heated Seat Module																																																															
K	2009	Silverado	Body	Rear HVAC/RSA																																																															
K	2009	Silverado	Body	Rollover Sensor																																																															
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																																															
K	2009	Silverado	Body	Theft Deterrent Module																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																													
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																															
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																															
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module			V																																																												
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																																															
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module				V																																																											
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																																															
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																																															
K	2009	Silverado Hybrid	Body	Body Control Module																																																															
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																																															
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																																															
K	2009	Silverado Hybrid	Body	Driver Door Switch																																																															
K	2009	Silverado Hybrid	Body	HVAC Control Module																																																															
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																																															
K	2009	Silverado Hybrid	Body	Memory Seat Module																																																															
K	2009	Silverado Hybrid	Body	Park Assist Module																																																															
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																																															
K	2009	Silverado Hybrid	Body	Passenger Presence System																																																															
K	2009	Silverado Hybrid	Body	Radio																																																															
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																																															
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																																															
K	2009	Silverado Hybrid	Body	Rollover Sensor																																																															
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																																															
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																															
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																																																															
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																															
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																															
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																															
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																															
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																															
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																															
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																															
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																											
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																											
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2009	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2009	Tahoe	Chassis	Electronic Suspension Control																																																											
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																																											
K	2009	Tahoe	Body	Amplifier (Bose)																																																											
K	2009	Tahoe	Body	Assist Step Controller																																																											
K	2009	Tahoe	Body	Body Control Module																																																											
K	2009	Tahoe	Body	Body Control Module (aux.)																																																											
K	2009	Tahoe	Body	Digital Radio Receiver																																																											
K	2009	Tahoe	Body	Driver Door Switch																																																											
K	2009	Tahoe	Body	HVAC Control Module Auto																																																											
K	2009	Tahoe	Body	HVAC Control Module Manual																																																											
K	2009	Tahoe	Body	Instrument Panel Cluster																																																											
K	2009	Tahoe	Body	Left Side Object Detection Module																																																											
K	2009	Tahoe	Body	Lift Gate Module																																																											
K	2009	Tahoe	Body	Memory Seat Module																																																											
K	2009	Tahoe	Body	Park Assist Module																																																											
K	2009	Tahoe	Body	Passenger Door Switch																																																											
K	2009	Tahoe	Body	Passenger Presence System																																																											
K	2009	Tahoe	Body	Radio																																																											
K	2009	Tahoe	Body	Rear Heated Seat Module																																																											
K	2009	Tahoe	Body	Rear HVAC/RSA																																																											
K	2009	Tahoe	Body	Right Side Object Detection Module																																																											
K	2009	Tahoe	Body	Rollover Sensor																																																											
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																																																											
K	2009	Tahoe	Body	Theft Deterrent Module																																																											
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																									
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																											
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																											
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module			V																																																								
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																											
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module				V																																																							
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																																											
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																																											
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																																											
K	2009	Tahoe Hybrid	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																																											
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																																												
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																																												
K	2009	Tahoe Hybrid	Body	HVAC Control Module																																																												
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
K	2009	Tahoe Hybrid	Body	Park Assist Module																																																												
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																																												
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																																												
K	2009	Tahoe Hybrid	Body	Radio																																																												
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																																												
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																												
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Avalanche	Chassis	Electronic Brake Control Module																																																												
K	2010	Avalanche	Chassis	Electronic Suspension Control																																																												
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Avalanche	Body	Amplifier (Bose)																																																												
K	2010	Avalanche	Body	Assist Step Controller																																																												
K	2010	Avalanche	Body	Body Control Module																																																												
K	2010	Avalanche	Body	Body Control Module (aux.)																																																												
K	2010	Avalanche	Body	Digital Radio Receiver																																																												
K	2010	Avalanche	Body	Driver Door Switch																																																												
K	2010	Avalanche	Body	HVAC Control Module Auto																																																												
K	2010	Avalanche	Body	HVAC Control Module Manual																																																												
K	2010	Avalanche	Body	Instrument Panel Cluster																																																												
K	2010	Avalanche	Body	Memory Seat Module																																																												
K	2010	Avalanche	Body	Park Assist Module																																																												
K	2010	Avalanche	Body	Passenger Door Switch																																																												
K	2010	Avalanche	Body	Passenger Presence System																																																												
K	2010	Avalanche	Body	Radio																																																											
K	2010	Avalanche	Body	Rear Heated Seat Module																																																												
K	2010	Avalanche	Body	Rear HVAC/RSA																																																												
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																																																											
K	2010	Avalanche	Body	Theft Deterrent Module																																																											
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																											
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Cheyenne	Body	Amplifier (Bose)																																																											
K	2010	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2010	Cheyenne	Body	Digital Radio Receiver																																																											
K	2010	Cheyenne	Body	Driver Door Switch																																																											
K	2010	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2010	Cheyenne	Body	Park Assist Module																																																											
K	2010	Cheyenne	Body	Passenger Door Switch																																																											
K	2010	Cheyenne	Body	Passenger Presence System																																																											
K	2010	Cheyenne	Body	Rear Heated Seat Module																																																											
K	2010	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
K	2010	Cheyenne	Body	Theft Deterrent Module																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																											
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2010	Suburban	Chassis	EBCM Under 8600 GVW																																																											
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2010	Suburban	Chassis	Electronic Suspension Control																																																											
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Suburban	Body	Amplifier (Bose)																																																											
K	2010	Suburban	Body	Assist Step Controller																																																											
K	2010	Suburban	Body	Body Control Module																																																											
K	2010	Suburban	Body	Body Control Module (aux.)																																																											
K	2010	Suburban	Body	Digital Radio Receiver																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2010	Suburban	Body	Driver Door Switch																																																											
K	2010	Suburban	Body	HVAC Control Module Auto																																																												
K	2010	Suburban	Body	HVAC Control Module Manual																																																												
K	2010	Suburban	Body	Instrument Panel Cluster																																																												
K	2010	Suburban	Body	Left Side Object Detection Module																																																												
K	2010	Suburban	Body	Lift Gate Module																																																												
K	2010	Suburban	Body	Memory Seat Module																																																												
K	2010	Suburban	Body	Park Assist Module																																																												
K	2010	Suburban	Body	Passenger Door Switch																																																												
K	2010	Suburban	Body	Passenger Presence System																																																												
K	2010	Suburban	Body	Radio																																																											
K	2010	Suburban	Body	Rear Heated Seat Module																																																												
K	2010	Suburban	Body	Rear HVAC/RSA																																																												
K	2010	Suburban	Body	Right Side Object Detection Module																																																												
K	2010	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2010	Suburban	Body	Theft Deterrent Module																																																												
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																																												
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2010	Silverado	Chassis	Electronic Suspension Control																																																													
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																													
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																																													
K	2010	Silverado	Body	Amplifier (Bose)																																																													
K	2010	Silverado	Body	Body Control Module																																																													
K	2010	Silverado	Body	Body Control Module (aux.)																																																													
K	2010	Silverado	Body	Digital Radio Receiver																																																													
K	2010	Silverado	Body	Driver Door Switch																																																													
K	2010	Silverado	Body	HVAC Control Module Auto																																																													
K	2010	Silverado	Body	HVAC Control Module Manual																																																													
K	2010	Silverado	Body	Instrument Panel Cluster																																																													
K	2010	Silverado	Body	Memory Seat Module																																																													
K	2010	Silverado	Body	Park Assist Module																																																													
K	2010	Silverado	Body	Passenger Door Switch																																																													
K	2010	Silverado	Body	Passenger Presence System																																																													
K	2010	Silverado	Body	Radio																																																													
K	2010	Silverado	Body	Rear Heated Seat Module																																																													
K	2010	Silverado	Body	Rear HVAC/RSA																																																													
K	2010	Silverado	Body	Supplemental Inflatable Restraint																																																													
K	2010	Silverado	Body	Theft Deterrent Module																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																											
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																													
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module			V																																																										
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																																														
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module				V																																																									
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																																														
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																																														
K	2010	Silverado Hybrid	Body	Body Control Module																																																														
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																																														
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																																														
K	2010	Silverado Hybrid	Body	Driver Door Switch																																																														
K	2010	Silverado Hybrid	Body	Heated Seat Module																																																														
K	2010	Silverado Hybrid	Body	HVAC Control Module																																																														
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																																														
K	2010	Silverado Hybrid	Body	Park Assist Module																																																														
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																																														
K	2010	Silverado Hybrid	Body	Passenger Presence System																																																														
K	2010	Silverado Hybrid	Body	Radio																																																														
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																																														
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																																														
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																																														
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																																																											
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2010	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Tahoe	Body	Amplifier (Bose)																																																												
K	2010	Tahoe	Body	Assist Step Controller																																																												
K	2010	Tahoe	Body	Body Control Module																																																												
K	2010	Tahoe	Body	Body Control Module (aux.)																																																												
K	2010	Tahoe	Body	Digital Radio Receiver																																																												
K	2010	Tahoe	Body	Driver Door Switch																																																												
K	2010	Tahoe	Body	HVAC Control Module Auto																																																												
K	2010	Tahoe	Body	HVAC Control Module Manual																																																												
K	2010	Tahoe	Body	Instrument Panel Cluster																																																												
K	2010	Tahoe	Body	Left Side Object Detection Module																																																												
K	2010	Tahoe	Body	Lift Gate Module																																																												
K	2010	Tahoe	Body	Memory Seat Module																																																												
K	2010	Tahoe	Body	Park Assist Module																																																												
K	2010	Tahoe	Body	Passenger Door Switch																																																												
K	2010	Tahoe	Body	Passenger Presence System																																																												
K	2010	Tahoe	Body	Radio																																																											
K	2010	Tahoe	Body	Rear Heated Seat Module																																																												
K	2010	Tahoe	Body	Rear HVAC/RSA																																																												
K	2010	Tahoe	Body	Right Side Object Detection Module																																																												
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2010	Tahoe	Body	Theft Deterrent Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																										
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module			V																																																									
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module				V																																																							
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Tahoe Hybrid	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																																																
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																																																
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																																																
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																																																
K	2010	Tahoe Hybrid	Body	HVAC Control Module																																																																
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																																																
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																																																
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																																																
K	2010	Tahoe Hybrid	Body	Park Assist Module																																																																
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																																																
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																																																
K	2010	Tahoe Hybrid	Body	Radio																																																																
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																																																
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																																																
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																																																
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																																																
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																																
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																																																
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																																
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																																
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																																
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																																
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																																
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module																																																																
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module																																																																
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																																
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																																
K	2011	Avalanche	Chassis	Electronic Brake Control Module																																																																
K	2011	Avalanche	Chassis	Electronic Suspension Control																																																																
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																																																
K	2011	Avalanche	Body	Amplifier (Bose)																																																																
K	2011	Avalanche	Body	Assist Step Controller																																																																
K	2011	Avalanche	Body	Body Control Module																																																																
K	2011	Avalanche	Body	Body Control Module (aux.)																																																																
K	2011	Avalanche	Body	Digital Radio Receiver																																																																
K	2011	Avalanche	Body	Driver Door Switch																																																																
K	2011	Avalanche	Body	HVAC Control Module Auto																																																																
K	2011	Avalanche	Body	HVAC Control Module Manual																																																																
K	2011	Avalanche	Body	Instrument Panel Cluster																																																																
K	2011	Avalanche	Body	Memory Seat Module																																																																
K	2011	Avalanche	Body	Park Assist Module																																																																
K	2011	Avalanche	Body	Passenger Door Switch																																																																
K	2011	Avalanche	Body	Passenger Presence System																																																																
K	2011	Avalanche	Body	Radio																																																																
K	2011	Avalanche	Body	Rear Heated Seat Module																																																																
K	2011	Avalanche	Body	Rear HVAC/RSA																																																																
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																																																
K	2011	Avalanche	Body	Theft Deterrent Module																																																																
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																																											
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																											
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																																											
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Cheyenne	Body	Amplifier (Bose)																																																											
K	2011	Cheyenne	Body	Body Control Module																																																											
K	2011	Cheyenne	Body	Body Control Module (aux.)																																																											
K	2011	Cheyenne	Body	Digital Radio Receiver																																																											
K	2011	Cheyenne	Body	Driver Door Switch																																																											
K	2011	Cheyenne	Body	Instrument Panel Cluster																																																											
K	2011	Cheyenne	Body	Park Assist Module																																																											
K	2011	Cheyenne	Body	Passenger Door Switch																																																											
K	2011	Cheyenne	Body	Passenger Presence System																																																											
K	2011	Cheyenne	Body	Rear Heated Seat Module																																																											
K	2011	Cheyenne	Body	Rear HVAC/RSA																																																											
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																																											
K	2011	Cheyenne	Body	Theft Deterrent Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																											
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																											
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2011	Suburban	Chassis	EBCM Under 8600 GVW																																																											
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2011	Suburban	Chassis	Electronic Suspension Control																																																											
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																																											
K	2011	Suburban	Body	Amplifier (Bose)																																																											
K	2011	Suburban	Body	Assist Step Controller																																																											
K	2011	Suburban	Body	Body Control Module																																																											
K	2011	Suburban	Body	Body Control Module (aux.)																																																											
K	2011	Suburban	Body	Digital Radio Receiver																																																											
K	2011	Suburban	Body	Driver Door Switch																																																											
K	2011	Suburban	Body	HVAC Control Module Auto																																																											
K	2011	Suburban	Body	HVAC Control Module Manual																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2011	Suburban	Body	Instrument Panel Cluster																																																												
K	2011	Suburban	Body	Left Side Object Detection Module																																																												
K	2011	Suburban	Body	Lift Gate Module																																																												
K	2011	Suburban	Body	Memory Seat Module																																																												
K	2011	Suburban	Body	Park Assist Module																																																												
K	2011	Suburban	Body	Passenger Door Switch																																																												
K	2011	Suburban	Body	Passenger Presence System																																																												
K	2011	Suburban	Body	Radio																																																												
K	2011	Suburban	Body	Rear Heated Seat Module																																																												
K	2011	Suburban	Body	Rear HVAC/RSA																																																												
K	2011	Suburban	Body	Right Side Object Detection Module																																																												
K	2011	Suburban	Body	Supplemental Inflatable Restraint																																																												
K	2011	Suburban	Body	Theft Deterrent Module																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V	V	V	V	V	V	V	V																																														
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module															V	V	V																																									
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																														
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																									
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																												
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													
K	2011	Silverado	Chassis	Electronic Suspension Control																																																														
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																																														
K	2011	Silverado	Body	Amplifier (Bose)																																																														
K	2011	Silverado	Body	Body Control Module																																																														
K	2011	Silverado	Body	Body Control Module (aux.)																																																														
K	2011	Silverado	Body	Digital Radio Receiver																																																														
K	2011	Silverado	Body	Driver Door Switch																																																														
K	2011	Silverado	Body	HVAC Control Module Auto																																																														
K	2011	Silverado	Body	HVAC Control Module Manual																																																														
K	2011	Silverado	Body	Instrument Panel Cluster																																																														
K	2011	Silverado	Body	Memory Seat Module																																																														
K	2011	Silverado	Body	Park Assist Module																																																														
K	2011	Silverado	Body	Passenger Door Switch																																																														
K	2011	Silverado	Body	Passenger Presence System																																																														
K	2011	Silverado	Body	Radio																																																														
K	2011	Silverado	Body	Rear Heated Seat Module																																																														
K	2011	Silverado	Body	Rear HVAC/RSA																																																														
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																																														
K	2011	Silverado	Body	Theft Deterrent Module																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																												
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																														
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module			V																																																											
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																																															
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module				V																																																										
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																																															
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																																															
K	2011	Silverado Hybrid	Body	Body Control Module																																																															
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																																															
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																																															
K	2011	Silverado Hybrid	Body	Driver Door Switch																																																															
K	2011	Silverado Hybrid	Body	Heated Seat Module																																																															
K	2011	Silverado Hybrid	Body	HVAC Control Module																																																															
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																																															
K	2011	Silverado Hybrid	Body	Park Assist Module																																																															
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																																															
K	2011	Silverado Hybrid	Body	Passenger Presence System																																																															
K	2011	Silverado Hybrid	Body	Radio																																																															
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																																															
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																																															
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																																															
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																																																											
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2011	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2011	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Tahoe	Body	Amplifier (Bose)																																																												
K	2011	Tahoe	Body	Assist Step Controller																																																												
K	2011	Tahoe	Body	Body Control Module																																																												
K	2011	Tahoe	Body	Body Control Module (aux.)																																																												
K	2011	Tahoe	Body	Digital Radio Receiver																																																												
K	2011	Tahoe	Body	Driver Door Switch																																																												
K	2011	Tahoe	Body	HVAC Control Module Auto																																																												
K	2011	Tahoe	Body	HVAC Control Module Manual																																																												
K	2011	Tahoe	Body	Instrument Panel Cluster																																																												
K	2011	Tahoe	Body	Left Side Object Detection Module																																																												
K	2011	Tahoe	Body	Lift Gate Module																																																												
K	2011	Tahoe	Body	Memory Seat Module																																																												
K	2011	Tahoe	Body	Park Assist Module																																																												
K	2011	Tahoe	Body	Passenger Door Switch																																																												
K	2011	Tahoe	Body	Passenger Presence System																																																												
K	2011	Tahoe	Body	Radio																																																												
K	2011	Tahoe	Body	Rear Heated Seat Module																																																												
K	2011	Tahoe	Body	Rear HVAC/RSA																																																												
K	2011	Tahoe	Body	Right Side Object Detection Module																																																												
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2011	Tahoe	Body	Theft Deterrent Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																										
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module			V																																																									
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module				V																																																								
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
K	2011	Tahoe Hybrid	Body	Body Control Module																																																												
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																																												
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																																												
K	2011	Tahoe Hybrid	Body	HVAC Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																																														
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																																														
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																																														
K	2011	Tahoe Hybrid	Body	Park Assist Module																																																														
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																																														
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																																														
K	2011	Tahoe Hybrid	Body	Radio																																																														
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																																														
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																																														
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																																														
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																																														
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																														
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																																														
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																														
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																														
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																														
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																														
K	2012	Avalanche	Chassis	Electronic Brake Control Module																																																														
K	2012	Avalanche	Chassis	Electronic Suspension Control																																																														
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																																														
K	2012	Avalanche	Body	Amplifier (Bose)																																																														
K	2012	Avalanche	Body	Assist Step Controller																																																														
K	2012	Avalanche	Body	Body Control Module																																																														
K	2012	Avalanche	Body	Body Control Module (aux.)																																																														
K	2012	Avalanche	Body	Digital Radio Receiver																																																														
K	2012	Avalanche	Body	Driver Door Switch																																																														
K	2012	Avalanche	Body	HVAC Control Module Auto																																																														
K	2012	Avalanche	Body	HVAC Control Module Manual																																																														
K	2012	Avalanche	Body	Instrument Panel Cluster																																																														
K	2012	Avalanche	Body	Memory Seat Module																																																														
K	2012	Avalanche	Body	Navigation Radio																																																														
K	2012	Avalanche	Body	Park Assist Module																																																														
K	2012	Avalanche	Body	Passenger Door Switch																																																														
K	2012	Avalanche	Body	Passenger Presence System																																																														
K	2012	Avalanche	Body	Radio																																																														
K	2012	Avalanche	Body	Rear Heated Seat Module																																																														
K	2012	Avalanche	Body	Rear HVAC/RSA																																																														
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																																														
K	2012	Avalanche	Body	Theft Deterrent Module																																																														
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																														
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																														
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																																												
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
K	2012	Cheyenne	Body	Amplifier (Bose)																																																												
K	2012	Cheyenne	Body	Body Control Module																																																												
K	2012	Cheyenne	Body	Body Control Module (aux.)																																																												
K	2012	Cheyenne	Body	Digital Radio Receiver																																																												
K	2012	Cheyenne	Body	Driver Door Switch																																																												
K	2012	Cheyenne	Body	Instrument Panel Cluster																																																												
K	2012	Cheyenne	Body	Park Assist Module																																																												
K	2012	Cheyenne	Body	Passenger Door Switch																																																												
K	2012	Cheyenne	Body	Passenger Presence System																																																												
K	2012	Cheyenne	Body	Rear Heated Seat Module																																																												
K	2012	Cheyenne	Body	Rear HVAC/RSA																																																												
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																																												
K	2012	Cheyenne	Body	Theft Deterrent Module																																																												
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2012	Suburban	Chassis	EBCM Under 8600 GVW																																																												
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2012	Suburban	Chassis	Electronic Suspension Control																																																												
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2012	Suburban	Body	Amplifier (Bose)																																																												
K	2012	Suburban	Body	Assist Step Controller																																																												
K	2012	Suburban	Body	Body Control Module																																																												
K	2012	Suburban	Body	Body Control Module (aux.)																																																												
K	2012	Suburban	Body	Digital Radio Receiver																																																												
K	2012	Suburban	Body	Driver Door Switch																																																												
K	2012	Suburban	Body	HVAC Control Module Auto																																																												
K	2012	Suburban	Body	HVAC Control Module Manual																																																												
K	2012	Suburban	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2012	Suburban	Body	Left Side Object Detection Module																																																												
K	2012	Suburban	Body	Lift Gate Module																																																													
K	2012	Suburban	Body	Memory Seat Module																																																													
K	2012	Suburban	Body	Navigation Radio																																																													
K	2012	Suburban	Body	Park Assist Module																																																													
K	2012	Suburban	Body	Passenger Door Switch																																																													
K	2012	Suburban	Body	Passenger Presence System																																																													
K	2012	Suburban	Body	Radio																																																													
K	2012	Suburban	Body	Rear Heated Seat Module																																																													
K	2012	Suburban	Body	Rear HVAC/RSA																																																													
K	2012	Suburban	Body	Right Side Object Detection Module																																																													
K	2012	Suburban	Body	Supplemental Inflatable Restraint																																																													
K	2012	Suburban	Body	Theft Deterrent Module																																																													
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																													
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																													
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																													
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																													
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																													
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																													
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																													
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																													
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																													
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																													
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																													
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module															V	V	V																																											
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																													
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																													
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																													
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																											
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																													
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																													
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																													
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																													
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2012	Silverado	Chassis	Electronic Suspension Control																																																												
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2012	Silverado	Body	Amplifier (Bose)																																																												
K	2012	Silverado	Body	Body Control Module																																																												
K	2012	Silverado	Body	Body Control Module (aux.)																																																												
K	2012	Silverado	Body	Digital Radio Receiver																																																												
K	2012	Silverado	Body	Driver Door Switch																																																												
K	2012	Silverado	Body	HVAC Control Module Auto																																																												
K	2012	Silverado	Body	HVAC Control Module Manual																																																												
K	2012	Silverado	Body	Instrument Panel Cluster																																																												
K	2012	Silverado	Body	Memory Seat Module																																																												
K	2012	Silverado	Body	Navigation Radio																																																												
K	2012	Silverado	Body	Park Assist Module																																																												
K	2012	Silverado	Body	Passenger Door Switch																																																												
K	2012	Silverado	Body	Passenger Presence System																																																												
K	2012	Silverado	Body	Radio																																																												
K	2012	Silverado	Body	Rear Heated Seat Module																																																												
K	2012	Silverado	Body	Rear HVAC/RSA																																																												
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2012	Silverado	Body	Theft Deterrent Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																										
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module			V																																																									
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module				V																																																								
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2012	Silverado Hybrid	Body	Body Control Module																																																												
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2012	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2012	Silverado Hybrid	Body	Heated Seat Module																																																												
K	2012	Silverado Hybrid	Body	HVAC Control Module																																																												
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2012	Silverado Hybrid	Body	Navigation Radio																																																												
K	2012	Silverado Hybrid	Body	Park Assist Module																																																												
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2012	Silverado Hybrid	Body	Passenger Presence System																																																												
K	2012	Silverado Hybrid	Body	Radio																																																												
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2012	Silverado Hybrid	Body	Theft Deterrent Module																																																											
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2012	Tahoe	Chassis	EBCM with Trailer Brake																																																												
K	2012	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2012	Tahoe	Body	Amplifier (Bose)																																																												
K	2012	Tahoe	Body	Assist Step Controller																																																												
K	2012	Tahoe	Body	Body Control Module																																																												
K	2012	Tahoe	Body	Body Control Module (aux.)																																																												
K	2012	Tahoe	Body	Digital Radio Receiver																																																												
K	2012	Tahoe	Body	Driver Door Switch																																																												
K	2012	Tahoe	Body	HVAC Control Module Auto																																																												
K	2012	Tahoe	Body	HVAC Control Module Manual																																																												
K	2012	Tahoe	Body	Instrument Panel Cluster																																																												
K	2012	Tahoe	Body	Left Side Object Detection Module																																																												
K	2012	Tahoe	Body	Lift Gate Module																																																												
K	2012	Tahoe	Body	Memory Seat Module																																																												
K	2012	Tahoe	Body	Navigation Radio																																																												
K	2012	Tahoe	Body	Park Assist Module																																																												
K	2012	Tahoe	Body	Passenger Door Switch																																																												
K	2012	Tahoe	Body	Passenger Presence System																																																												
K	2012	Tahoe	Body	Radio																																																											
K	2012	Tahoe	Body	Rear Heated Seat Module																																																												
K	2012	Tahoe	Body	Rear HVAC/RSA																																																												
K	2012	Tahoe	Body	Right Side Object Detection Module																																																												
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2012	Tahoe	Body	Theft Deterrent Module																																																												
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																										
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module			V																																																									
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module				V																																																							
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																																												
K	2012	Tahoe Hybrid	Body	Body Control Module																																																												
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																																												
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2012	Tahoe Hybrid	Body	HVAC Control Module																																																												
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																																												
K	2012	Tahoe Hybrid	Body	Navigation Radio																																																												
K	2012	Tahoe Hybrid	Body	Park Assist Module																																																												
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																																												
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																																												
K	2012	Tahoe Hybrid	Body	Radio																																																												
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2013	Avalanche	Chassis	Electronic Brake Control Module																																																												
K	2013	Avalanche	Chassis	Electronic Suspension Control																																																												
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Avalanche	Body	Amplifier (Bose)																																																												
K	2013	Avalanche	Body	Assist Step Controller																																																												
K	2013	Avalanche	Body	Body Control Module																																																												
K	2013	Avalanche	Body	Body Control Module (aux.)																																																												
K	2013	Avalanche	Body	Digital Radio Receiver																																																												
K	2013	Avalanche	Body	Driver Door Switch																																																												
K	2013	Avalanche	Body	HVAC Control Module Auto																																																												
K	2013	Avalanche	Body	HVAC Control Module Manual																																																												
K	2013	Avalanche	Body	Instrument Panel Cluster																																																												
K	2013	Avalanche	Body	Memory Seat Module																																																												
K	2013	Avalanche	Body	Navigation Radio																																																												
K	2013	Avalanche	Body	Park Assist Module																																																												
K	2013	Avalanche	Body	Passenger Door Switch																																																												
K	2013	Avalanche	Body	Passenger Presence System																																																												
K	2013	Avalanche	Body	Radio																																																											
K	2013	Avalanche	Body	Rear Heated Seat Module																																																												
K	2013	Avalanche	Body	Rear HVAC/RSA																																																												
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																																																												
K	2013	Avalanche	Body	Theft Deterrent Module																																																												
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																												
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																												
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																																												
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																																												
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Cheyenne	Body	Amplifier (Bose)																																																												
K	2013	Cheyenne	Body	Body Control Module																																																												
K	2013	Cheyenne	Body	Body Control Module (aux.)																																																												
K	2013	Cheyenne	Body	Digital Radio Receiver																																																												
K	2013	Cheyenne	Body	Driver Door Switch																																																												
K	2013	Cheyenne	Body	Instrument Panel Cluster																																																												
K	2013	Cheyenne	Body	Park Assist Module																																																												
K	2013	Cheyenne	Body	Passenger Door Switch																																																												
K	2013	Cheyenne	Body	Passenger Presence System																																																												
K	2013	Cheyenne	Body	Rear Heated Seat Module																																																												
K	2013	Cheyenne	Body	Rear HVAC/RSA																																																												
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																																												
K	2013	Cheyenne	Body	Theft Deterrent Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																																												
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
K	2013	Suburban	Chassis	EBCM Under 8600 GVW																																																												
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2013	Suburban	Chassis	Electronic Suspension Control																																																												
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Suburban	Body	Amplifier (Bose)																																																												
K	2013	Suburban	Body	Assist Step Controller																																																												
K	2013	Suburban	Body	Body Control Module																																																												
K	2013	Suburban	Body	Body Control Module (aux.)																																																												
K	2013	Suburban	Body	Digital Radio Receiver																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2013	Suburban	Body	Driver Door Switch																																																												
K	2013	Suburban	Body	HVAC Control Module Auto																																																													
K	2013	Suburban	Body	HVAC Control Module Manual																																																													
K	2013	Suburban	Body	Instrument Panel Cluster																																																													
K	2013	Suburban	Body	Left Side Object Detection Module																																																													
K	2013	Suburban	Body	Lift Gate Module																																																													
K	2013	Suburban	Body	Memory Seat Module																																																													
K	2013	Suburban	Body	Navigation Radio																																																													
K	2013	Suburban	Body	Park Assist Module																																																													
K	2013	Suburban	Body	Passenger Door Switch																																																													
K	2013	Suburban	Body	Passenger Presence System																																																													
K	2013	Suburban	Body	Radio																																																													
K	2013	Suburban	Body	Rear Heated Seat Module																																																													
K	2013	Suburban	Body	Rear HVAC/RSA																																																													
K	2013	Suburban	Body	Right Side Object Detection Module																																																													
K	2013	Suburban	Body	Supplemental Inflatable Restraint																																																													
K	2013	Suburban	Body	Theft Deterrent Module																																																													
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																																													
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																																													
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																													
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																													
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																																													
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																																													
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																													
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																													
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																													
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V	V	V					V							V																																								
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module															V	V	V																																											
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																													
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																													
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																													
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																																												
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2013	Silverado	Chassis	Electronic Suspension Control																																																												
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																																												
K	2013	Silverado	Body	Amplifier (Bose)																																																												
K	2013	Silverado	Body	Body Control Module																																																												
K	2013	Silverado	Body	Body Control Module (aux.)																																																												
K	2013	Silverado	Body	Digital Radio Receiver																																																												
K	2013	Silverado	Body	Driver Door Switch																																																												
K	2013	Silverado	Body	HVAC Control Module Auto																																																												
K	2013	Silverado	Body	HVAC Control Module Manual																																																												
K	2013	Silverado	Body	Instrument Panel Cluster																																																												
K	2013	Silverado	Body	Memory Seat Module																																																												
K	2013	Silverado	Body	Navigation Radio																																																												
K	2013	Silverado	Body	Park Assist Module																																																												
K	2013	Silverado	Body	Passenger Door Switch																																																												
K	2013	Silverado	Body	Passenger Presence System																																																												
K	2013	Silverado	Body	Radio																																																												
K	2013	Silverado	Body	Rear Heated Seat Module																																																												
K	2013	Silverado	Body	Rear HVAC/RSA																																																												
K	2013	Silverado	Body	Supplemental Inflatable Restraint																																																												
K	2013	Silverado	Body	Theft Deterrent Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																										
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module			V																																																									
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																																												
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module				V																																																								
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																																												
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																																												
K	2013	Silverado Hybrid	Body	Body Control Module																																																												
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																																												
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																																												
K	2013	Silverado Hybrid	Body	Driver Door Switch																																																												
K	2013	Silverado Hybrid	Body	Heated Seat Module																																																												
K	2013	Silverado Hybrid	Body	HVAC Control Module																																																												
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																																												
K	2013	Silverado Hybrid	Body	Navigation Radio																																																												
K	2013	Silverado Hybrid	Body	Park Assist Module																																																												
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																																												
K	2013	Silverado Hybrid	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2013	Silverado Hybrid	Body	Radio																																																											
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																																												
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																																												
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																																												
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																																																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2013	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2013	Tahoe	Chassis	Electronic Suspension Control																																																												
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Tahoe	Body	Amplifier (Bose)																																																												
K	2013	Tahoe	Body	Assist Step Controller																																																												
K	2013	Tahoe	Body	Body Control Module																																																												
K	2013	Tahoe	Body	Body Control Module (aux.)																																																												
K	2013	Tahoe	Body	Digital Radio Receiver																																																												
K	2013	Tahoe	Body	Driver Door Switch																																																												
K	2013	Tahoe	Body	HVAC Control Module Auto																																																												
K	2013	Tahoe	Body	HVAC Control Module Manual																																																												
K	2013	Tahoe	Body	Instrument Panel Cluster																																																												
K	2013	Tahoe	Body	Left Side Object Detection Module																																																												
K	2013	Tahoe	Body	Lift Gate Module																																																												
K	2013	Tahoe	Body	Memory Seat Module																																																												
K	2013	Tahoe	Body	Navigation Radio																																																												
K	2013	Tahoe	Body	Park Assist Module																																																												
K	2013	Tahoe	Body	Passenger Door Switch																																																												
K	2013	Tahoe	Body	Passenger Presence System																																																												
K	2013	Tahoe	Body	Radio																																																											
K	2013	Tahoe	Body	Rear Heated Seat Module																																																												
K	2013	Tahoe	Body	Rear HVAC/RSA																																																												
K	2013	Tahoe	Body	Right Side Object Detection Module																																																												
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																																												
K	2013	Tahoe	Body	Theft Deterrent Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																										
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module			V																																																									
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																																												
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module				V																																																							
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																																												
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																																													
K	2013	Tahoe Hybrid	Body	Body Control Module																																																													
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																																												
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																																												
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																																												
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																																												
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																																												
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																																												
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																																												
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																																												
K	2013	Tahoe Hybrid	Body	Navigation Radio																																																												
K	2013	Tahoe Hybrid	Body	Park Assist Module																																																												
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																																												
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																																												
K	2013	Tahoe Hybrid	Body	Radio																																																												
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																																												
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																																												
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																																												
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																																												
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																																												
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																						V																																					
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																																												
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																																												
K	2014	Cheyenne	Chassis	Power Steering Control Module																																																												
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2014	Cheyenne	Body	Body Control Module																																																												
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Cheyenne	Body	Passenger Presence Module																																																												
K	2014	Cheyenne	Body	Instrument Cluster																																																												
K	2014	Cheyenne	Body	Radio Control																																																												
K	2014	Cheyenne	Body	HVAC Control																																																												
K	2014	Cheyenne	Body	Radio																																																											
K	2014	Cheyenne	Body	Amplifier																																																											
K	2014	Cheyenne	Body	Media Disc Player																																																												
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																																												
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2014	Cheyenne	Body	HVAC Control Module																																																											
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																																												
K	2014	Cheyenne	Body	Parking Assist Control Module																																																												
K	2014	Cheyenne	Body	Frontview Camera Module																																																												
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																							V																																				
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2014	Silverado	Chassis	Electronic Brake Control Module																																																												
K	2014	Silverado	Chassis	Parking Brake Control Module																																																												
K	2014	Silverado	Chassis	Power Steering Control Module																																																												
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2014	Silverado	Body	Body Control Module																																																												
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Silverado	Body	Passenger Presence Module																																																												
K	2014	Silverado	Body	Instrument Cluster																																																												
K	2014	Silverado	Body	Radio Control																																																												
K	2014	Silverado	Body	HVAC Control																																																												
K	2014	Silverado	Body	Radio																																																												
K	2014	Silverado	Body	Amplifier																																																												
K	2014	Silverado	Body	Media Disc Player																																																												
K	2014	Silverado	Body	Human Machine Interface Control Module																																																												
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																																												
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																												
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																												
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																												
K	2014	Silverado	Body	Parking Assist Control Module																																																												
K	2014	Silverado	Body	Frontview Camera Module																																																												
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																																												
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																						V																																					
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																						V																																					
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module							V																	V	V	V	V	V	V	V	V																												
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																							V																																				
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																																												
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																																												
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2014	Silverado HD	Chassis	Suspension Control Module																																																											
K	2014	Silverado HD	Body	Body Control Module																																																												
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Silverado HD	Body	Passenger Presence Module																																																												
K	2014	Silverado HD	Body	Instrument Cluster																																																												
K	2014	Silverado HD	Body	Chime Alarm Control Module																																																												
K	2014	Silverado HD	Body	Base Radio																																																												
K	2014	Silverado HD	Body	Navigation Radio																																																												
K	2014	Silverado HD	Body	Uplevel Radio																																																												
K	2014	Silverado HD	Body	Amplifier																																																												
K	2014	Silverado HD	Body	Rear Audio Control Module																																																												
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																																												
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																																												
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																																												
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																																												
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																																												
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																																												
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																																												
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																																												
K	2014	Silverado HD	Body	Seat Memory Control Module																																																												
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																																												
K	2014	Silverado HD	Body	Parking Assist Control Module																																																												
K	2014	Silverado HD	Body	Theft Deterrent Module																																																												
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																																												
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																												
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																																												
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																												
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2014	Suburban	Chassis	Electronic Brake Control Module																																																												
K	2014	Suburban	Chassis	Parking Brake Control Module																																																												
K	2014	Suburban	Chassis	Suspension Control Module																																																												
K	2014	Suburban	Body	Body Control Module																																																												
K	2014	Suburban	Body	Auxiliary Body Control Module																																																												
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2014	Suburban	Body	Passenger Presence Module																																																												
K	2014	Suburban	Body	Instrument Cluster																																																												
K	2014	Suburban	Body	Base Radio																																																												
K	2014	Suburban	Body	Navigation Radio																																																												
K	2014	Suburban	Body	Uplevel Radio																																																												
K	2014	Suburban	Body	Amplifier																																																												
K	2014	Suburban	Body	Rear Audio Control Module																																																												
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																																												
K	2014	Suburban	Body	Personal Audio Link Control Module																																																												
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																																												
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																																											
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																																											
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																																											
K	2014	Suburban	Body	Liftgate Control Module																																																											
K	2014	Suburban	Body	Seat Memory Control Module																																																											
K	2014	Suburban	Body	Rear Seat Heating Control Module																																																											
K	2014	Suburban	Body	Assist Step Control Module																																																											
K	2014	Suburban	Body	Right Side Object Detection Control Module																																																											
K	2014	Suburban	Body	Left Side Object Detection Control Module																																																											
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																																											
K	2014	Suburban	Body	Parking Assist Control Module																																																											
K	2014	Suburban	Body	Theft Deterrent Module																																																											
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																																											
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																											
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																																											
K	2014	Tahoe	Chassis	Parking Brake Control Module																																																											
K	2014	Tahoe	Chassis	Suspension Control Module																																																											
K	2014	Tahoe	Body	Body Control Module																																																											
K	2014	Tahoe	Body	Auxiliary Body Control Module																																																											
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2014	Tahoe	Body	Passenger Presence Module																																																											
K	2014	Tahoe	Body	Instrument Cluster																																																											
K	2014	Tahoe	Body	Base Radio																																																											
K	2014	Tahoe	Body	Navigation Radio																																																											
K	2014	Tahoe	Body	Uplevel Radio																																																											
K	2014	Tahoe	Body	Amplifier																																																											
K	2014	Tahoe	Body	Rear Audio Control Module																																																											
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																																											
K	2014	Tahoe	Body	Personal Audio Link Control Module																																																											
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																																											
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																											
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																																											
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																																											
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																																											
K	2014	Tahoe	Body	Liftgate Control Module																																																											
K	2014	Tahoe	Body	Seat Memory Control Module																																																											
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																																											
K	2014	Tahoe	Body	Assist Step Control Module																																																											
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																																											
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																																											
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																																											
K	2014	Tahoe	Body	Parking Assist Control Module																																																											
K	2014	Tahoe	Body	Theft Deterrent Module																																																											
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																						V																																				
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																																											
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																																											
K	2015	Cheyenne	Chassis	Power Steering Control Module																																																											
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																											
K	2015	Cheyenne	Chassis	Suspension Control Module																																																											
K	2015	Cheyenne	Body	Body Control Module																																																											
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
K	2015	Cheyenne	Body	Passenger Presence Module																																																											
K	2015	Cheyenne	Body	Instrument Cluster																																																											
K	2015	Cheyenne	Body	Radio Controls																																																											
K	2015	Cheyenne	Body	HVAC Controls																																																											
K	2015	Cheyenne	Body	Radio																																																											
K	2015	Cheyenne	Body	Amplifier																																																											
K	2015	Cheyenne	Body	Media Disc Player																																																											
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																																											
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																																											
K	2015	Cheyenne	Body	HVAC Control Module																																																											
K	2015	Cheyenne	Body	Parking Assist Control Module																																																											
K	2015	Cheyenne	Body	Frontview Camera Module																																																											
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																						V																																				
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																						V																																				
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module							V																	V	V	V	V	V	V	V	V																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																											
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																							V																																				

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																																															
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																																															
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																															
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																															
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																															
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																															
K	2015	Silverado	Chassis	Electronic Brake Control Module																																																															
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																																															
K	2015	Silverado	Chassis	Power Steering Control Module																																																															
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																															
K	2015	Silverado	Chassis	Suspension Control Module																																																															
K	2015	Silverado	Body	Body Control Module																																																															
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
K	2015	Silverado	Body	Passenger Presence Module																																																															
K	2015	Silverado	Body	Instrument Cluster																																																															
K	2015	Silverado	Body	Radio Controls																																																															
K	2015	Silverado	Body	HVAC Controls																																																															
K	2015	Silverado	Body	Radio																																																															
K	2015	Silverado	Body	Amplifier																																																															
K	2015	Silverado	Body	Media Disc Player																																																															
K	2015	Silverado	Body	Human Machine Interface Control Module																																																															
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																																															
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																															
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																															
K	2015	Silverado	Body	Parking Assist Control Module																																																															
K	2015	Silverado	Body	Frontview Camera Module																																																															
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																															
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																															
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																																															
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																																															
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																																															
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																																															
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																															
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																																															
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																															
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																															
K	2015	Suburban	Chassis	Electronic Brake Control Module																																																															
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																																															
K	2015	Suburban	Chassis	Parking Brake Control Module																																																															
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																																															
K	2015	Suburban	Chassis	Power Steering Control Module																																																															
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																															
K	2015	Suburban	Chassis	Suspension Control Module																																																															
K	2015	Suburban	Body	Body Control Module																																																															
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
K	2015	Suburban	Body	Passenger Presence Module																																																															
K	2015	Suburban	Body	Instrument Cluster																																																															
K	2015	Suburban	Body	Radio Controls																																																															
K	2015	Suburban	Body	HVAC Controls																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2015	Suburban	Body	Radio																																																												
K	2015	Suburban	Body	Amplifier																																																												
K	2015	Suburban	Body	Media Disc Player																																																												
K	2015	Suburban	Body	Human Machine Interface Control Module																																																												
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																																												
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																																												
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																																												
K	2015	Suburban	Body	HVAC Control Module																																																												
K	2015	Suburban	Body	Liftgate Control Module																																																												
K	2015	Suburban	Body	Keyless Entry Control Module																																																												
K	2015	Suburban	Body	Assist Step Control Module																																																												
K	2015	Suburban	Body	Left Side Object Detection Control Module																																																												
K	2015	Suburban	Body	Parking Assist Control Module																																																												
K	2015	Suburban	Body	Frontview Camera Module																																																												
K	2015	Suburban	Body	Steering Column Lock Control Module																																																												
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																																												
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																																												
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																																												
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																																												
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																																												
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																																												
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																												
K	2015	Tahoe	Chassis	Parking Brake Control Module																																																												
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																																												
K	2015	Tahoe	Chassis	Power Steering Control Module																																																												
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																												
K	2015	Tahoe	Chassis	Suspension Control Module																																																												
K	2015	Tahoe	Body	Body Control Module																																																												
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
K	2015	Tahoe	Body	Passenger Presence Module																																																												
K	2015	Tahoe	Body	Instrument Cluster																																																												
K	2015	Tahoe	Body	Radio Controls																																																												
K	2015	Tahoe	Body	HVAC Controls																																																												
K	2015	Tahoe	Body	Radio																																																												
K	2015	Tahoe	Body	Amplifier																																																												
K	2015	Tahoe	Body	Media Disc Player																																																												
K	2015	Tahoe	Body	Human Machine Interface Control Module																																																												
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																																												
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																																												
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																																												
K	2015	Tahoe	Body	HVAC Control Module																																																												
K	2015	Tahoe	Body	Liftgate Control Module																																																												
K	2015	Tahoe	Body	Keyless Entry Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2015	Tahoe	Body	Assist Step Control Module																																																										
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																																										
K	2015	Tahoe	Body	Parking Assist Control Module																																																										
K	2015	Tahoe	Body	Frontview Camera Module																																																										
K	2015	Tahoe	Body	Steering Column Lock Control Module																																																										
K	2015	Tahoe	Body	Battery Energy Control Module																																																										
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																																										
K	2016	Cheyenne	Chassis	Power Steering Control Module																																																										
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																																										
K	2016	Cheyenne	Chassis	Suspension Control Module																																																										
K	2016	Cheyenne	Body	Body Control Module																																																										
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
K	2016	Cheyenne	Body	Passenger Presence Module																																																										
K	2016	Cheyenne	Body	Instrument Cluster																																																										
K	2016	Cheyenne	Body	Radio Controls																																																										
K	2016	Cheyenne	Body	HVAC Controls																																																										
K	2016	Cheyenne	Body	Radio																																																										
K	2016	Cheyenne	Body	Amplifier																																																										
K	2016	Cheyenne	Body	Media Disc Player																																																										
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																																										
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																																										
K	2016	Cheyenne	Body	HVAC Control Module																																																										
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																																										
K	2016	Cheyenne	Body	Parking Assist Control Module																																																										
K	2016	Cheyenne	Body	Frontview Camera Module																																																										
K	2016	Cheyenne	Body	Frontview Camera Module																																																										
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																															V	V	V																									
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																							V																																			
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																							V																																			
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																													
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module							V																	V	V	V	V	V	V	V	V																														
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																													
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																																													
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																							V																																						
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																													
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																													
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
K	2016	Silverado	Chassis	Electronic Brake Control Module																																																														
K	2016	Silverado	Chassis	Power Steering Control Module																																			V	V	V																										
K	2016	Silverado	Chassis	Power Steering Control Module																																																													
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																																														
K	2016	Silverado	Chassis	Suspension Control Module																																																														
K	2016	Silverado	Body	Body Control Module																																																														
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
K	2016	Silverado	Body	Passenger Presence Module																																																														
K	2016	Silverado	Body	Instrument Cluster																																																														
K	2016	Silverado	Body	Radio Controls																																																														
K	2016	Silverado	Body	HVAC Controls																																																														
K	2016	Silverado	Body	Radio (IO3)																																																														
K	2016	Silverado	Body	Radio (IOB)																																																														
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																																														
K	2016	Silverado	Body	Amplifier																																																														
K	2016	Silverado	Body	Media Disc Player																																																														
K	2016	Silverado	Body	Human Machine Interface Control Module																																																														
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																																														
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																																														
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																																														
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																																														
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																																														
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																																														
K	2016	Silverado	Body	Parking Assist Control Module																																																														
K	2016	Silverado	Body	Frontview Camera Module																																																														
K	2016	Silverado	Body	Frontview Camera Module																																																														
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																																														
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																																														
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																						V																																								
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																																														
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
K	2016	Suburban	Chassis	Electronic Brake Control Module																																																														
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																																														
K	2016	Suburban	Chassis	Parking Brake Control Module																																																														
K	2016	Suburban	Chassis	Power Steering Control Module																																																														
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																																														
K	2016	Suburban	Chassis	Suspension Control Module																																																														
K	2016	Suburban	Body	Body Control Module																																																														
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2016	Suburban	Body	Passenger Presence Module																																																														
K	2016	Suburban	Body	Instrument Cluster																																																															
K	2016	Suburban	Body	Radio Controls																																																															
K	2016	Suburban	Body	HVAC Controls																																																															
K	2016	Suburban	Body	Radio																																																															
K	2016	Suburban	Body	Amplifier																																																															
K	2016	Suburban	Body	Media Disc Player																																																															
K	2016	Suburban	Body	Human Machine Interface Control Module																																																															
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																																															
K	2016	Suburban	Body	HVAC Control Module																																																															
K	2016	Suburban	Body	Liftgate Control Module																																																															
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																																															
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																																															
K	2016	Suburban	Body	Keyless Entry Control Module																																																															
K	2016	Suburban	Body	Assist Step Control Module																																																															
K	2016	Suburban	Body	Left Side Object Detection Control Module																																																															
K	2016	Suburban	Body	Parking Assist Control Module																																																															
K	2016	Suburban	Body	Frontview Camera Module																																																															
K	2016	Suburban	Body	Steering Column Lock Control Module																																																															
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																																															
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																																															
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																															
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																															
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																																															
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																																															
K	2016	Tahoe	Chassis	Parking Brake Control Module																																																															
K	2016	Tahoe	Chassis	Power Steering Control Module																																																															
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																																															
K	2016	Tahoe	Chassis	Suspension Control Module																																																															
K	2016	Tahoe	Body	Body Control Module																																																															
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
K	2016	Tahoe	Body	Passenger Presence Module																																																															
K	2016	Tahoe	Body	Instrument Cluster																																																															
K	2016	Tahoe	Body	Radio Controls																																																															
K	2016	Tahoe	Body	HVAC Controls																																																															
K	2016	Tahoe	Body	Radio																																																															
K	2016	Tahoe	Body	Amplifier																																																															
K	2016	Tahoe	Body	Media Disc Player																																																															
K	2016	Tahoe	Body	Human Machine Interface Control Module																																																															
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																																															
K	2016	Tahoe	Body	HVAC Control Module																																																															
K	2016	Tahoe	Body	Liftgate Control Module																																																															
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																																															
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																																															
K	2016	Tahoe	Body	Keyless Entry Control Module																																																															
K	2016	Tahoe	Body	Assist Step Control Module																																																															
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																																															
K	2016	Tahoe	Body	Parking Assist Control Module																																																															
K	2016	Tahoe	Body	Frontview Camera Module																																																															
K	2016	Tahoe	Body	Steering Column Lock Control Module																																																															
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																															
L	2004	ALL	Chassis	4WAL 3 Sensor																																																															
L	2004	ALL	Body	Body Control Module																																													V	V	V	V													
L	2004	ALL	Body	Instrument Panel Cluster																																																														
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																															
L	2005	Astro	Chassis	4WAL 3 Sensor																																																															
L	2005	Astro	Body	Body Control Module																																													V	V	V	V													
L	2005	Astro	Body	Instrument Panel Cluster																																																														
L	2005	Astro	Body	Supplemental Inflatable Restraint																																																															
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																															
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																															
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																																															
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																																															
L	2005	Equinox	Chassis	Electric Power Steering																																																															
L	2005	Equinox	Body	Body Control Module																																																						V	V	V	V	V	V	V	V
L	2005	Equinox	Body	Instrument Panel Cluster																																																															
L	2005	Equinox	Body	Radio																																																															
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																																															
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																															
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																															
L	2006	ALL	Chassis	Traction Control Yes																																																															
L	2006	ALL	Chassis	Traction Control No																																																															
L	2006	ALL	Chassis	Electric Power Steering																																																															
L	2006	ALL	Body	Body Control Module																																																V	V	V	V	V	V	V	V
L	2006	ALL	Body	Instrument Panel Cluster																																																															
L	2006	ALL	Body	Radio																																																															
L	2006	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																															
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																															
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																															
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																																															
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																																															
L	2007	ALL	Chassis	Power Steering Control Module																																																															
L	2007	ALL	Body	Body Control Module																																																															
L	2007	ALL	Body	Digital Radio Receiver																																																															
L	2007	ALL	Body	Heated Seat Module																																																															
L	2007	ALL	Body	HVAC Control Module																																																															
L	2007	ALL	Body	Instrument Panel Cluster																																																															
L	2007	ALL	Body	Passenger Presence System																																																															
L	2007	ALL	Body	Radio																																																															
L	2007	ALL	Body	Rollover Sensor																																																															
L	2007	ALL	Body	Supplemental Inflatable Restraint																																																															
L	2007	ALL	Body	Theft Deterrent Module																																																															
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																															
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																															
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																															
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																												
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																																													
L	2008	Captiva Sport	Body	Body Control Module																																																													
L	2008	Captiva Sport	Body	Digital Radio Receiver																																																													
L	2008	Captiva Sport	Body	HVAC Control Module Auto																																																													
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																																													
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																																													
L	2008	Captiva Sport	Body	Passenger Presence System																																																													
L	2008	Captiva Sport	Body	Radio																																																													
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																																													
L	2008	Captiva Sport	Body	Rollover Sensor																																																													
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																																													
L	2008	Captiva Sport	Body	Theft Deterrent Module																																																													
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																													
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																													
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																													
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																													
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
L	2008	Equinox	Chassis	Electronic Brake Control Module																																																													
L	2008	Equinox	Chassis	Power Steering Control Module																																																													
L	2008	Equinox	Body	Body Control Module																																																													
L	2008	Equinox	Body	Digital Radio Receiver																																																													
L	2008	Equinox	Body	Heated Seat Module																																																													
L	2008	Equinox	Body	HVAC Control Module																																																													
L	2008	Equinox	Body	Instrument Panel Cluster																																																													
L	2008	Equinox	Body	Passenger Presence System																																																													
L	2008	Equinox	Body	Radio																																																													
L	2008	Equinox	Body	Rollover Sensor																																																													
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																																													
L	2008	Equinox	Body	Theft Deterrent Module																																																													
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																																													
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																																													
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																													
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																													
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																													
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																													
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																													
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																																													
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																																													
L	2009	Captiva Sport	Body	Body Control Module																																																													
L	2009	Captiva Sport	Body	HVAC Control Module Auto																																																													
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																																													
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																																													
L	2009	Captiva Sport	Body	Passenger Presence System																																																													
L	2009	Captiva Sport	Body	Radio																																																													
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																																													
L	2009	Captiva Sport	Body	Rollover Sensor																																																													
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																																													
L	2009	Captiva Sport	Body	Theft Deterrent Module																																																													
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																																													
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																																														
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																														
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																														
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
L	2009	Equinox	Chassis	Electronic Brake Control Module																																																														
L	2009	Equinox	Chassis	Power Steering Control Module																																																														
L	2009	Equinox	Body	Body Control Module																																																														
L	2009	Equinox	Body	Digital Radio Receiver																																																														
L	2009	Equinox	Body	Heated Seat Module																																																														
L	2009	Equinox	Body	HVAC Control Module																																																														
L	2009	Equinox	Body	Instrument Panel Cluster																																																														
L	2009	Equinox	Body	Passenger Presence System																																																														
L	2009	Equinox	Body	Radio																																																														
L	2009	Equinox	Body	Rollover Sensor																																																														
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																																														
L	2009	Equinox	Body	Theft Deterrent Module																																																														
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																														
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																																														
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																														
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																																														
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																																														
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																																														
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																																														
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																																														
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																																														
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																																														
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																																														
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																																														
L	2010	Captiva Sport	Body	Body Control Module																																																														
L	2010	Captiva Sport	Body	HVAC Control Module																																																														
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																																														
L	2010	Captiva Sport	Body	Passenger Presence System																																																														
L	2010	Captiva Sport	Body	Radio																																																														
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																																														
L	2010	Captiva Sport	Body	Rollover Sensor																																																														
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																																														
L	2010	Captiva Sport	Body	Theft Deterrent Module																																																														
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																																														
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																																														
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																														
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																														
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																																														
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																																														
L	2010	Equinox	Chassis	Electronic Brake Control Module																																																														
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2010	Equinox	Body	Body Control Module																																																														
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2010	Equinox	Body	Passenger Presence Module																																																														
L	2010	Equinox	Body	Instrument Cluster																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2010	Equinox	Body	Radio																																																												
L	2010	Equinox	Body	Multimedia Player Interface Module																																																												
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2010	Equinox	Body	Liftgate Control Module																																																												
L	2010	Equinox	Body	Parking Assist Control Module																																																												
L	2010	Equinox	Body	Frontview Camera Module																																																												
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																																												
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																																												
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																																												
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
L	2011	Captiva	Chassis	Electronic Brake Control Module																																																												
L	2011	Captiva	Chassis	Parking Brake Control Module																																																												
L	2011	Captiva	Body	Body Control Module																																																												
L	2011	Captiva	Body	Auxiliary Body Control Module																																																												
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2011	Captiva	Body	Instrument Cluster																																																												
L	2011	Captiva	Body	Headlamp Control Module						V																																																					
L	2011	Captiva	Body	HVAC Control Module																																																												
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																																												
L	2011	Captiva	Body	Parking Assist Control Module																																																												
L	2011	Captiva	Body	Theft Deterrent Module																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																																												
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																																												
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																												
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module																																																															
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																																															
L	2011	Captiva Sport	Body	Body Control Module																																																															
L	2011	Captiva Sport	Body	Digital Radio Receiver																																																															
L	2011	Captiva Sport	Body	HVAC Control Module																																																															
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																																															
L	2011	Captiva Sport	Body	Passenger Presence System																																																															
L	2011	Captiva Sport	Body	Radio																																																															
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																																															
L	2011	Captiva Sport	Body	Rollover Sensor																																																															
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																																																															
L	2011	Captiva Sport	Body	Theft Deterrent Module																																																															
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																																															
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																																															
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																															
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																															
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																																															
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																																															
L	2011	Equinox	Chassis	Electronic Brake Control Module																																																															
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																															
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																															
L	2011	Equinox	Body	Body Control Module																																																															
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
L	2011	Equinox	Body	Passenger Presence Module																																																															
L	2011	Equinox	Body	Instrument Cluster																																																															
L	2011	Equinox	Body	Radio																																																															
L	2011	Equinox	Body	Multimedia Player Interface Module																																																															
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																															
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																															
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																																															
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																																															
L	2011	Equinox	Body	Liftgate Control Module																																																															
L	2011	Equinox	Body	Parking Assist Control Module																																																															
L	2011	Equinox	Body	Frontview Camera Module																																																															
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																																																															
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																															
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																															
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																															
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																															
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																															
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																															
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																															
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																															
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																																															
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																															
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																															
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																															
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																															
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																															
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																																															
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																																										
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																																											
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																																											
L	2012	Captiva	Chassis	Electronic Brake Control Module																																																											
L	2012	Captiva	Chassis	Parking Brake Control Module																																																											
L	2012	Captiva	Body	Body Control Module																																																											
L	2012	Captiva	Body	Auxiliary Body Control Module																																																											
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2012	Captiva	Body	Instrument Cluster																																																											
L	2012	Captiva	Body	Headlamp Control Module						V																																																					
L	2012	Captiva	Body	HVAC Control Module																																																											
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																																											
L	2012	Captiva	Body	Parking Assist Control Module																																																											
L	2012	Captiva	Body	Theft Deterrent Module																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																											
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																											
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																											
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module																																																											
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																																											
L	2012	Captiva Sport	Body	Body Control Module																																																											
L	2012	Captiva Sport	Body	Digital Radio Receiver																																																											
L	2012	Captiva Sport	Body	HVAC Control Module																																																											
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																																											
L	2012	Captiva Sport	Body	Passenger Presence System																																																											
L	2012	Captiva Sport	Body	Radio																																																											
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																																											
L	2012	Captiva Sport	Body	Rollover Sensor																																																											
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																																																											
L	2012	Captiva Sport	Body	Theft Deterrent Module																																																											
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																																											
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																																											
L	2012	Equinox	Chassis	Electronic Brake Control Module																																																											
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2012	Equinox	Body	Body Control Module																																																											
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2012	Equinox	Body	Passenger Presence Module																																																											
L	2012	Equinox	Body	Instrument Cluster																																																											
L	2012	Equinox	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2012	Equinox	Body	Multimedia Player Interface Module																																																												
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																																												
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																																												
L	2012	Equinox	Body	Liftgate Control Module																																																												
L	2012	Equinox	Body	Parking Assist Control Module																																																												
L	2012	Equinox	Body	Frontview Camera Module																																																												
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																																												
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																																												
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																																												
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																																												
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																																												
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																																												
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																												
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																												
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																																												
L	2013	Captiva	Chassis	Electronic Brake Control Module																																																												
L	2013	Captiva	Chassis	Parking Brake Control Module																																																												
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																																												
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																																												
L	2013	Captiva	Body	Auxiliary Body Control Module																																																												
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2013	Captiva	Body	Instrument Cluster																																																												
L	2013	Captiva	Body	Headlamp Control Module						V																																																					
L	2013	Captiva	Body	HVAC Control Module																																																												
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																																												
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																		V	V	V																																							
L	2013	Captiva	Body	Theft Deterrent Module																																																												
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																																												
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																																												
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																																												
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																																												
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																																												
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																																												
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																																												
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																																												
L	2013	Captiva Sport	Body	Body Control Module																																																												
L	2013	Captiva Sport	Body	Digital Radio Receiver																																																												
L	2013	Captiva Sport	Body	Heated Seat Module																																																												
L	2013	Captiva Sport	Body	HVAC Control Module																																																												
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2013	Captiva Sport	Body	Park Assist Module																																																												
L	2013	Captiva Sport	Body	Passenger Presence System																																																													
L	2013	Captiva Sport	Body	Radio																																																													
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																																													
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																																													
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																																													
L	2013	Captiva Sport	Body	Theft Deterrent Module																																																													
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																													
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																																													
L	2013	Equinox	Chassis	Electronic Brake Control Module																																																													
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																													
L	2013	Equinox	Chassis	Power Steering Control Module																																																													
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																													
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																																													
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																													
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
L	2013	Equinox	Body	Passenger Presence Module																																																													
L	2013	Equinox	Body	Instrument Cluster																																																													
L	2013	Equinox	Body	Radio																																																													
L	2013	Equinox	Body	Rear Audio Control Module																																																													
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																													
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																													
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																																													
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																																													
L	2013	Equinox	Body	Liftgate Control Module																																																													
L	2013	Equinox	Body	Front Seat Heating Control Module																																																													
L	2013	Equinox	Body	Right Side Object Detection Control Module																																																													
L	2013	Equinox	Body	Left Side Object Detection Control Module																																																													
L	2013	Equinox	Body	Parking Assist Control Module																																																													
L	2013	Equinox	Body	Frontview Camera Module																																																													
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																													
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																													
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																													
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																													
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																																													
L	2014	Captiva (3GN)	Body	Body Control Module																																																													
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																																													
L	2014	Captiva (3GN)	Body	Instrument Cluster																					V																																							
L	2014	Captiva (3GN)	Body	Radio																																																													
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																													
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																												
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2014	Captiva (3GN)	Body	HVAC Control Module																																																													
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																											
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																																											
L	2014	Captiva (3GN)	Body	Theft Deterrent Module																																																											
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																											
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																											
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																																											
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																											
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																																											
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																																											
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																											
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																											
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																																											
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2014	Captiva (Other)	Body	Instrument Cluster																																																											
L	2014	Captiva (Other)	Body	Headlamp Control Module						V																																																					
L	2014	Captiva (Other)	Body	HVAC Control Module																																																											
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																											
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																		V	V	V																																						
L	2014	Captiva (Other)	Body	Theft Deterrent Module																																																											
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																																											
L	2014	Equinox	Chassis	Electronic Brake Control Module																																																											
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2014	Equinox	Chassis	Power Steering Control Module																																																											
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																																											
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2014	Equinox	Body	Passenger Presence Module																																																											
L	2014	Equinox	Body	Instrument Cluster																																																											
L	2014	Equinox	Body	Radio																																																											
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																																											
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2014	Equinox	Body	Liftgate Control Module																																																															
L	2014	Equinox	Body	Right Side Object Detection Control Module																																																															
L	2014	Equinox	Body	Left Side Object Detection Control Module																																																															
L	2014	Equinox	Body	Parking Assist Control Module																																																															
L	2014	Equinox	Body	Frontview Camera Module																																																															
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																															
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																															
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																															
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																															
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																															
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																															
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																																															
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																															
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																																															
L	2015	Captiva (3GN)	Body	Body Control Module																																																															
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																																															
L	2015	Captiva (3GN)	Body	Instrument Cluster																						V																																								
L	2015	Captiva (3GN)	Body	Radio																																																															
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																															
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																																															
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																															
L	2015	Captiva (3GN)	Body	HVAC Control Module																																																															
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																																															
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																															
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																																																															
L	2015	Captiva (3GN)	Body	Theft Deterrent Module																																																															
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																															
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																															
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																															
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																															
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																															
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																															
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																															
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																															
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																															
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																															
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																															
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																															
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																																															
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																															
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																																															
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																																															
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																															
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																															
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																																															
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
L	2015	Captiva (Other)	Body	Instrument Cluster																																																															
L	2015	Captiva (Other)	Body	Headlamp Control Module						V																																																								
L	2015	Captiva (Other)	Body	HVAC Control Module																																																															
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																		V	V	V																																								
L	2015	Captiva (Other)	Body	Theft Deterrent Module																																																													
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																													
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																																													
L	2015	Equinox	Chassis	Electronic Brake Control Module																																																													
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																													
L	2015	Equinox	Chassis	Power Steering Control Module																																																													
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																													
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																																													
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																													
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
L	2015	Equinox	Body	Passenger Presence Module																																																													
L	2015	Equinox	Body	Instrument Cluster																																																													
L	2015	Equinox	Body	Radio																																																													
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																																													
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																																													
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																																													
L	2015	Equinox	Body	Liftgate Control Module																																																													
L	2015	Equinox	Body	Right Side Object Detection Control Module																																																													
L	2015	Equinox	Body	Left Side Object Detection Control Module																																																													
L	2015	Equinox	Body	Parking Assist Control Module																																																													
L	2015	Equinox	Body	Frontview Camera Module																																																													
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																																													
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																																													
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																													
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																																													
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																																													
L	2016	Captiva (3GN)	Body	Body Control Module																																																													
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
L	2016	Captiva (3GN)	Body	Instrument Cluster																						V																																							
L	2016	Captiva (3GN)	Body	Radio																																																													
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																																													
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																																													
L	2016	Captiva (3GN)	Body	HVAC Control Module																																																													
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																																													
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																																													
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																																													
L	2016	Captiva (3GN)	Body	Theft Deterrent Module																																																													
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																																													
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																																													
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																																													
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																																													
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																																													
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																																													
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																																										
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																																										
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																																										
L	2016	Captiva (Other)	Chassis	Power Steering Control Module																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																																										
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																																										
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																																										
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Captiva (Other)	Body	Instrument Cluster																																																										
L	2016	Captiva (Other)	Body	Headlamp Control Module						V																																																				
L	2016	Captiva (Other)	Body	Radio																																																										
L	2016	Captiva (Other)	Body	HVAC Control Module																																																										
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																																										
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																		V	V	V																																						
L	2016	Captiva (Other)	Body	Theft Deterrent Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Equinox	Chassis	Electronic Brake Control Module																																																										
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2016	Equinox	Chassis	Power Steering Control Module																																																										
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate																																																										
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Equinox	Body	Passenger Presence Module																																																										
L	2016	Equinox	Body	Instrument Cluster																																																										
L	2016	Equinox	Body	Radio																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																																										
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																																																										
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																																																										
L	2016	Equinox	Body	Liftgate Control Module																																																										
L	2016	Equinox	Body	Seat Memory Control Module																																																										
L	2016	Equinox	Body	Right Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Left Side Object Detection Control Module																																																										
L	2016	Equinox	Body	Parking Assist Control Module																																																										
L	2016	Equinox	Body	Frontview Camera Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
M	2004	ALL	Chassis	4WAL 3 Sensor																																																											
M	2004	ALL	Body	Body Control Module																																														V	V	V	V										
M	2004	ALL	Body	Instrument Panel Cluster																																																											
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
M	2005	ALL	Chassis	4WAL 3 Sensor																																																											
M	2005	ALL	Body	Body Control Module																																														V	V	V	V										
M	2005	ALL	Body	Instrument Panel Cluster																																																											
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
P	2007	ALL	Body	Theft Deterrent Module																																																											
R	2009	ALL	Powertrain	Engine Control Module																																																											
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2009	ALL	Powertrain	Transmission Control Module																																																											
R	2009	ALL	Chassis	Electronic Brake Control Module																																																											
R	2009	ALL	Body	Body Control Module																																																										
R	2009	ALL	Body	Digital Radio Receiver																																																											
R	2009	ALL	Body	Driver Door Switch																																																											
R	2009	ALL	Body	Heated Seat Module																																																											
R	2009	ALL	Body	HVAC Control Module Auto																																																											
R	2009	ALL	Body	HVAC Control Module Manual																																																											
R	2009	ALL	Body	Instrument Panel Cluster																																																											
R	2009	ALL	Body	Lift Gate Module																																																											
R	2009	ALL	Body	Park Assist Module																																																											
R	2009	ALL	Body	Passenger Door Switch																																																											
R	2009	ALL	Body	Passenger Presence System																																																											
R	2009	ALL	Body	Radio																																																											
R	2009	ALL	Body	Rear HVAC/RSA																																																											
R	2009	ALL	Body	Rollover Sensor																																																											
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2009	ALL	Body	Theft Deterrent Module																																																											
R	2010	ALL	Powertrain	Engine Control Module																																																											
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2010	ALL	Powertrain	Transmission Control Module																																																											
R	2010	ALL	Chassis	Electronic Brake Control Module																																																											
R	2010	ALL	Body	Body Control Module																																																											
R	2010	ALL	Body	Digital Radio Receiver																																																											
R	2010	ALL	Body	Driver Door Switch																																																											
R	2010	ALL	Body	Heated Seat Module																																																											
R	2010	ALL	Body	HVAC Control Module Auto																																																											
R	2010	ALL	Body	HVAC Control Module Manual																																																											
R	2010	ALL	Body	Instrument Panel Cluster																																																											
R	2010	ALL	Body	Lift Gate Module																																																											
R	2010	ALL	Body	Park Assist Module																																																											
R	2010	ALL	Body	Passenger Door Switch																																																											
R	2010	ALL	Body	Passenger Presence System																																																											
R	2010	ALL	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
R	2010	ALL	Body	Rear HVAC/RSA																																																												
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																													
R	2010	ALL	Body	Theft Deterrent Module																																																													
R	2011	ALL	Powertrain	Engine Control Module																																																													
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																													
R	2011	ALL	Powertrain	Transmission Control Module																																																													
R	2011	ALL	Chassis	Electronic Brake Control Module																																																													
R	2011	ALL	Body	Body Control Module																																																													
R	2011	ALL	Body	Digital Radio Receiver																																																													
R	2011	ALL	Body	Driver Door Switch																																																													
R	2011	ALL	Body	Heated Seat Module																																																													
R	2011	ALL	Body	HVAC Control Module Auto																																																													
R	2011	ALL	Body	HVAC Control Module Manual																																																													
R	2011	ALL	Body	Instrument Panel Cluster																																																													
R	2011	ALL	Body	Lift Gate Module																																																													
R	2011	ALL	Body	Park Assist Module																																																													
R	2011	ALL	Body	Passenger Door Switch																																																													
R	2011	ALL	Body	Passenger Presence System																																																													
R	2011	ALL	Body	Radio																																																													
R	2011	ALL	Body	Rear HVAC/RSA																																																													
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																													
R	2011	ALL	Body	Theft Deterrent Module																																																													
R	2012	ALL	Powertrain	Engine Control Module																																																													
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																													
R	2012	ALL	Powertrain	Transmission Control Module																																																													
R	2012	ALL	Chassis	Electronic Brake Control Module																																																													
R	2012	ALL	Body	Body Control Module																																																													
R	2012	ALL	Body	Digital Radio Receiver																																																													
R	2012	ALL	Body	Driver Door Switch																																																													
R	2012	ALL	Body	Heated Seat Module																																																													
R	2012	ALL	Body	HVAC Control Module Auto																																																													
R	2012	ALL	Body	HVAC Control Module Manual																																																													
R	2012	ALL	Body	Instrument Panel Cluster																																																													
R	2012	ALL	Body	Lift Gate Module																																																													
R	2012	ALL	Body	Park Assist Module																																																													
R	2012	ALL	Body	Passenger Door Switch																																																													
R	2012	ALL	Body	Passenger Presence System																																																													
R	2012	ALL	Body	Radio																																																													
R	2012	ALL	Body	Rear HVAC/RSA																																																													
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																													
R	2012	ALL	Body	Theft Deterrent Module																																																													
R	2013	ALL	Powertrain	Engine Control Module																																																														
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																													
R	2013	ALL	Powertrain	Transmission Control Module																																																													
R	2013	ALL	Chassis	Electronic Brake Control Module																																																													
R	2013	ALL	Body	Body Control Module																																																													
R	2013	ALL	Body	Digital Radio Receiver																																																													
R	2013	ALL	Body	Driver Door Switch																																																													
R	2013	ALL	Body	Heated Seat Module																																																													
R	2013	ALL	Body	HVAC Control Module Auto																																																													
R	2013	ALL	Body	HVAC Control Module Manual																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
R	2013	ALL	Body	Instrument Panel Cluster																																																													
R	2013	ALL	Body	Left Side Object Detection Module																																																													
R	2013	ALL	Body	Lift Gate Module																																																													
R	2013	ALL	Body	Park Assist Module																																																												
R	2013	ALL	Body	Passenger Door Switch																																																												
R	2013	ALL	Body	Passenger Presence System																																																												
R	2013	ALL	Body	Radio																																																												
R	2013	ALL	Body	Rear HVAC/RSA																																																												
R	2013	ALL	Body	Right Side Object Detection Module																																																												
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2013	ALL	Body	Theft Deterrent Module																																																												
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2014	Traverse	Powertrain	Chassis Control Module																																																												
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
R	2014	Traverse	Chassis	Electronic Brake Control Module																																																												
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																												
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Traverse	Body	Passenger Presence Module																																																												
R	2014	Traverse	Body	Instrument Cluster																																																												
R	2014	Traverse	Body	Radio																																																												
R	2014	Traverse	Body	Rear Audio Control Module																																																												
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																																												
R	2014	Traverse	Body	Personal Audio Link Control Module																																																												
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																												
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																												
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																												
R	2014	Traverse	Body	Liftgate Control Module																																																												
R	2014	Traverse	Body	Seat Memory Control Module																																																												
R	2014	Traverse	Body	Front Seat Heating Control Module																																																												
R	2014	Traverse	Body	Right Side Object Detection Control Module																																																												
R	2014	Traverse	Body	Left Side Object Detection Control Module																																																												
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																																												
R	2014	Traverse	Body	Parking Assist Control Module																																																												
R	2014	Traverse	Body	Frontview Camera Module																																																												
R	2014	Traverse	Body	Theft Deterrent Module																																																												
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
R	2015	Traverse	Chassis	Electronic Brake Control Module																																																												
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																												
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Traverse	Body	Passenger Presence Module																																																												
R	2015	Traverse	Body	Instrument Cluster																																																												
R	2015	Traverse	Body	Radio																																																												
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																													
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																														
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																														
R	2015	Traverse	Body	Liftgate Control Module																																																														
R	2015	Traverse	Body	Seat Memory Control Module																																																														
R	2015	Traverse	Body	Front Seat Heating Control Module																																																														
R	2015	Traverse	Body	Right Side Object Detection Control Module																																																														
R	2015	Traverse	Body	Left Side Object Detection Control Module																																																														
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																																														
R	2015	Traverse	Body	Parking Assist Control Module																																																														
R	2015	Traverse	Body	Frontview Camera Module																																																														
R	2015	Traverse	Body	Theft Deterrent Module																																																														
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																														
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																														
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																														
R	2016	Traverse	Chassis	Electronic Brake Control Module																																																														
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																														
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																														
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
R	2016	Traverse	Body	Passenger Presence Module																																																														
R	2016	Traverse	Body	Instrument Cluster																																																														
R	2016	Traverse	Body	Radio																																																														
R	2016	Traverse	Body	Rear Audio Control Module																																																														
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																																														
R	2016	Traverse	Body	Personal Audio Link Control Module																																																														
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																																														
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																														
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																														
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																														
R	2016	Traverse	Body	Liftgate Control Module																																																														
R	2016	Traverse	Body	Seat Memory Control Module																																																														
R	2016	Traverse	Body	Front Seat Heating Control Module																																																														
R	2016	Traverse	Body	Right Side Object Detection Control Module																																																														
R	2016	Traverse	Body	Left Side Object Detection Control Module																																																														
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																																														
R	2016	Traverse	Body	Parking Assist Control Module																																																														
R	2016	Traverse	Body	Frontview Camera Module																																																														
R	2016	Traverse	Body	Theft Deterrent Module																																																														
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
S	2004	S10	Chassis	4WAL 3 Sensor																																																														
S	2004	S10	Chassis	Traction Assist (If Equipped)																																																														
S	2004	S10	Body	Body Control Module																																													V	V	V	V												
S	2004	S10	Body	Instrument Panel Cluster																																																													
S	2004	S10	Body	Base Radio																																																														
S	2004	S10	Body	Uplevel Radio																																																														
S	2004	S10	Body	Supplemental Inflatable Restraint																																																														
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																														
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																														
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																															
S	2004	Colorado	Chassis	ABS Without Traction Control																																																															
S	2004	Colorado	Chassis	ABS With Traction Control																																																															
S	2004	Colorado	Body	Body Control Module																																																						V									
S	2004	Colorado	Body	Instrument Panel Cluster																																																															
S	2004	Colorado	Body	OnStar																																																															
S	2004	Colorado	Body	Base Radio																																																															
S	2004	Colorado	Body	Uplevel Radio																																																															
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																																															
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																															
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																															
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																															
S	2004	TrailBlazer	Body	Amplifier (Bose)																																																															
S	2004	TrailBlazer	Body	Body Control Module																																																															
S	2004	TrailBlazer	Body	Driver Door Module																																																															
S	2004	TrailBlazer	Body	Driver Seat Module																																																															
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																															
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																															
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																																															
S	2004	TrailBlazer	Body	Lift Gate Module																																																															
S	2004	TrailBlazer	Body	OnStar																																																															
S	2004	TrailBlazer	Body	Passenger Door Module																																																															
S	2004	TrailBlazer	Body	Uplevel Radio																																																															
S	2004	TrailBlazer	Body	Navigation Radio																																																															
S	2004	TrailBlazer	Body	Rear Seat Audio																																																															
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																																															
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																															
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																															
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																															
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																															
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																															
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																															
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																															
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																															
S	2004	TrailBlazer EXT	Body	Body Control Module																																																															
S	2004	TrailBlazer EXT	Body	Driver Door Module																																																															
S	2004	TrailBlazer EXT	Body	Driver Seat Module																																																															
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																															
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																															
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																															
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																																															
S	2004	TrailBlazer EXT	Body	OnStar																																																															
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																																															
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																																															
S	2004	TrailBlazer EXT	Body	Navigation Radio																																																															
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																															
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																															
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																															
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																															
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
S	2004	Blazer	Chassis	4WAL 3 Sensor																																																															
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																															
S	2004	Blazer	Body	Body Control Module																																																					V	V	V	V								
S	2004	Blazer	Body	Heating and Air Conditioning																																																															
S	2004	Blazer	Body	Instrument Panel Cluster																																																															
S	2004	Blazer	Body	Memory Seat Module																																																															
S	2004	Blazer	Body	Base Radio																																																															
S	2004	Blazer	Body	Uplevel Radio																																																															
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																																															
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																															
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																															
S	2004	SSR	Chassis	4WAL 3 Sensor																																																															
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																																															
S	2004	SSR	Body	Amplifier (Bose)																																																															
S	2004	SSR	Body	Body Control Module																																																															
S	2004	SSR	Body	Driver Seat Module																																																															
S	2004	SSR	Body	Instrument Panel Cluster																																																															
S	2004	SSR	Body	Uplevel Radio																																																															
S	2004	SSR	Body	Remote Function Actuation																																																															
S	2004	SSR	Body	Roof and Door Module																																																															
S	2004	SSR	Body	Supplemental Inflatable Restraint																																																															
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																															
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																															
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																															
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																															
S	2005	Colorado	Chassis	ABS Without Traction Control																																																															
S	2005	Colorado	Chassis	ABS With Traction Control																																																															
S	2005	Colorado	Body	Body Control Module																																																							V									
S	2005	Colorado	Body	Instrument Panel Cluster																																																															
S	2005	Colorado	Body	Base Radio																																																															
S	2005	Colorado	Body	Uplevel Radio																																																															
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																																															
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																																															
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																															
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																															
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																															
S	2005	TrailBlazer	Body	Body Control Module																																																															
S	2005	TrailBlazer	Body	Disc Player and Video Display																																																															
S	2005	TrailBlazer	Body	Driver Door Module																																																															
S	2005	TrailBlazer	Body	Driver Seat Module																																																															
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																															
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																															
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2005	TrailBlazer	Body	Lift Gate Module																																																															
S	2005	TrailBlazer	Body	Passenger Door Module																																																															
S	2005	TrailBlazer	Body	Passenger Presence System																																																															
S	2005	TrailBlazer	Body	Uplevel Radio																																																															
S	2005	TrailBlazer	Body	Navigation Radio																																																															
S	2005	TrailBlazer	Body	Rear Seat Audio																																																															
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																															
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																															
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																															
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																															
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																															
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																															
S	2005	TrailBlazer EXT	Body	Body Control Module																																																															
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																															
S	2005	TrailBlazer EXT	Body	Driver Door Module																																																															
S	2005	TrailBlazer EXT	Body	Driver Seat Module																																																															
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																															
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																															
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																															
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																																															
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																																															
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																																															
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																																															
S	2005	TrailBlazer EXT	Body	Navigation Radio																																																															
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																															
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																															
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																															
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																															
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																															
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																															
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
S	2005	Blazer	Chassis	4WAL 3 Sensor																																																															
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																															
S	2005	Blazer	Body	Body Control Module																																													V	V	V	V													
S	2005	Blazer	Body	Heating and Air Conditioning																																																															
S	2005	Blazer	Body	Instrument Panel Cluster																																																															
S	2005	Blazer	Body	Memory Seat Module																																																															
S	2005	Blazer	Body	Base Radio																																																															
S	2005	Blazer	Body	Uplevel Radio																																																															
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																																															
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
S	2005	SSR	Chassis	4WAL 3 Sensor																																																															
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																																															
S	2005	SSR	Body	Amplifier (Bose)																																																															
S	2005	SSR	Body	Body Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2005	SSR	Body	Driver Seat Module																																																															
S	2005	SSR	Body	Instrument Panel Cluster																																																															
S	2005	SSR	Body	Uplevel Radio																																																															
S	2005	SSR	Body	Remote Function Actuation																																																															
S	2005	SSR	Body	Roof and Door Module																																																															
S	2005	SSR	Body	Supplemental Inflatable Restraint																																																															
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																																
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																																
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																																
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																																
S	2006	Colorado	Chassis	ABS Without Traction Control																																																																
S	2006	Colorado	Chassis	ABS With Traction Control																																																																
S	2006	Colorado	Body	Body Control Module																																																							V									
S	2006	Colorado	Body	Instrument Panel Cluster																																																																
S	2006	Colorado	Body	Passenger Presence System																																																																
S	2006	Colorado	Body	Base Radio																																																																
S	2006	Colorado	Body	Uplevel Radio																																																																
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																																																
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																																																
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																																
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																																
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																																
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																																
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																																
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																																
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																																
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																																
S	2006	TrailBlazer	Body	Body Control Module																																																																
S	2006	TrailBlazer	Body	Disc Player and Video Display																																																																
S	2006	TrailBlazer	Body	Driver Door Module																																																																
S	2006	TrailBlazer	Body	Driver Seat Module																																																																
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																																
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																																
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																																																
S	2006	TrailBlazer	Body	Lift Gate Module																																																																
S	2006	TrailBlazer	Body	Passenger Door Module																																																																
S	2006	TrailBlazer	Body	Passenger Presence System																																																																
S	2006	TrailBlazer	Body	Uplevel Radio																																																																
S	2006	TrailBlazer	Body	Navigation Radio																																																																
S	2006	TrailBlazer	Body	Rear Seat Audio																																																																
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																																
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																																
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																																
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																																
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																																
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																																
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																																
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																															
S	2006	TrailBlazer EXT	Body	Body Control Module																																																																
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																																
S	2006	TrailBlazer EXT	Body	Driver Door Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2006	TrailBlazer EXT	Body	Driver Seat Module																																																															
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																															
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																															
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																															
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																																															
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																																															
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																																															
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																																															
S	2006	TrailBlazer EXT	Body	Navigation Radio																																																															
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																															
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																															
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																															
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																															
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																															
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																															
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
S	2006	SSR	Chassis	4WAL 3 Sensor																																																															
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																																															
S	2006	SSR	Body	Amplifier (Bose)																																																															
S	2006	SSR	Body	Body Control Module																																																															
S	2006	SSR	Body	Driver Seat Module																																																															
S	2006	SSR	Body	Instrument Panel Cluster																																																															
S	2006	SSR	Body	Uplevel Radio																																																															
S	2006	SSR	Body	Remote Function Actuation																																																															
S	2006	SSR	Body	Roof and Door Module																																																															
S	2006	SSR	Body	Supplemental Inflatable Restraint																																																															
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																															
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																															
S	2007	Colorado	Body	Body Control Module																																																								V										
S	2007	Colorado	Body	Digital Radio Receiver																																																															
S	2007	Colorado	Body	Generator Battery Control Module																																																															
S	2007	Colorado	Body	Instrument Panel Cluster																																																															
S	2007	Colorado	Body	Passenger Presence System																																																															
S	2007	Colorado	Body	Base Radio																																																															
S	2007	Colorado	Body	Uplevel Radio																																																															
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																																															
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																																															
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																															
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																															
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2007	Trailblazer	Body	Body Control Module																																																															
S	2007	Trailblazer	Body	Digital Radio Receiver																																																															
S	2007	Trailblazer	Body	Disc Player and Video Display																																																															
S	2007	Trailblazer	Body	Driver Door Module																																																															
S	2007	Trailblazer	Body	Driver Seat Module																																																															
S	2007	Trailblazer	Body	Generator Battery Control Module																																																															
S	2007	Trailblazer	Body	HVAC Control Module Auto																																																															
S	2007	Trailblazer	Body	HVAC Control Module Manual																																																															
S	2007	Trailblazer	Body	Instrument Panel Cluster																																																															
S	2007	Trailblazer	Body	Lift Gate Module																																																															
S	2007	Trailblazer	Body	Passenger Door Module																																																															
S	2007	Trailblazer	Body	Passenger Presence System																																																															
S	2007	Trailblazer	Body	Uplevel Radio																																																															
S	2007	Trailblazer	Body	Navigation Radio																																																															
S	2007	Trailblazer	Body	Rear Seat Audio																																																															
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																															
S	2007	Trailblazer	Body	Theft Deterrent Module																																																															
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																															
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																															
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																															
S	2008	Colorado	Body	Body Control Module																																																						V										
S	2008	Colorado	Body	Digital Radio Receiver																																																															
S	2008	Colorado	Body	Generator Battery Control Module																																																															
S	2008	Colorado	Body	Instrument Panel Cluster																																																															
S	2008	Colorado	Body	Passenger Presence System																																																															
S	2008	Colorado	Body	Base Radio																																																															
S	2008	Colorado	Body	Uplevel Radio																																																															
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																																															
S	2008	Colorado	Body	Theft Deterrent Module																																																															
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																																															
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																															
S	2008	TrailBlazer	Body	Body Control Module																																																															
S	2008	TrailBlazer	Body	Digital Radio Receiver																																																															
S	2008	TrailBlazer	Body	Disc Player and Video Display																																																															
S	2008	TrailBlazer	Body	Driver Door Module																																																															
S	2008	TrailBlazer	Body	Driver Seat Module																																																															
S	2008	TrailBlazer	Body	Generator Battery Control Module																																																															
S	2008	TrailBlazer	Body	HVAC Control Module Auto																																																															
S	2008	TrailBlazer	Body	HVAC Control Module Manual																																																															
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																																															
S	2008	TrailBlazer	Body	Lift Gate Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2008	TrailBlazer	Body	Passenger Door Module																																																														
S	2008	TrailBlazer	Body	Passenger Presence System																																																														
S	2008	TrailBlazer	Body	Uplevel Radio																																																														
S	2008	TrailBlazer	Body	Navigation Radio																																																														
S	2008	TrailBlazer	Body	Rear Seat Audio																																																														
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																														
S	2008	TrailBlazer	Body	Theft Deterrent Module																																																														
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																														
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																														
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																														
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																														
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																														
S	2009	Colorado	Chassis	Electronic Brake Control Module																																																															
S	2009	Colorado	Body	Body Control Module																																																							V									
S	2009	Colorado	Body	Digital Radio Receiver																																																															
S	2009	Colorado	Body	Generator Battery Control Module																																																															
S	2009	Colorado	Body	Instrument Panel Cluster																																																															
S	2009	Colorado	Body	Passenger Presence System																																																															
S	2009	Colorado	Body	Base Radio																																																															
S	2009	Colorado	Body	Uplevel Radio																																																															
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																																															
S	2009	Colorado	Body	Theft Deterrent Module																																																															
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																															
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																															
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																															
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																															
S	2009	TrailBlazer	Body	Body Control Module																																																															
S	2009	TrailBlazer	Body	Digital Radio Receiver																																																															
S	2009	TrailBlazer	Body	Disc Player and Video Display																																																															
S	2009	TrailBlazer	Body	Driver Door Module																																																															
S	2009	TrailBlazer	Body	Driver Seat Module																																																															
S	2009	TrailBlazer	Body	Generator Battery Control Module																																																															
S	2009	TrailBlazer	Body	HVAC Control Module Auto																																																															
S	2009	TrailBlazer	Body	HVAC Control Module Manual																																																															
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																																															
S	2009	TrailBlazer	Body	Lift Gate Module																																																															
S	2009	TrailBlazer	Body	Passenger Door Module																																																															
S	2009	TrailBlazer	Body	Passenger Presence System																																																															
S	2009	TrailBlazer	Body	Uplevel Radio																																																															
S	2009	TrailBlazer	Body	Navigation Radio																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2009	TrailBlazer	Body	Rear Seat Audio																																																														
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																														
S	2009	TrailBlazer	Body	Theft Deterrent Module																																																														
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																															
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																															
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																															
S	2010	ALL	Chassis	Electronic Brake Control Module																																																															
S	2010	ALL	Body	Body Control Module																																																					V										
S	2010	ALL	Body	Digital Radio Receiver																																																															
S	2010	ALL	Body	Generator Battery Control Module																																																															
S	2010	ALL	Body	Instrument Panel Cluster																																																															
S	2010	ALL	Body	Passenger Presence System																																																															
S	2010	ALL	Body	Personal Audio Link Module																																																															
S	2010	ALL	Body	Base Radio																																																															
S	2010	ALL	Body	Uplevel Radio																																																															
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
S	2010	ALL	Body	Theft Deterrent Module																																																															
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																															
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																															
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																															
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																															
S	2011	ALL	Chassis	Electronic Brake Control Module																																																															
S	2011	ALL	Body	Body Control Module																																																					V										
S	2011	ALL	Body	Digital Radio Receiver																																																															
S	2011	ALL	Body	Generator Battery Control Module																																																															
S	2011	ALL	Body	Instrument Panel Cluster																																																															
S	2011	ALL	Body	Passenger Presence System																																																															
S	2011	ALL	Body	Personal Audio Link Module																																																															
S	2011	ALL	Body	Base Radio																																																															
S	2011	ALL	Body	Uplevel Radio																																																															
S	2011	ALL	Body	Supplemental Inflatable Restraint																																																															
S	2011	ALL	Body	Theft Deterrent Module																																																															
S	2011	ALL	Body	Vehicle Comm. Interface Module																																																															
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																														
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																														
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																														
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																														
S	2012	Colorado (First Gen)	Body	Body Control Module																																																						V									
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																														
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																														
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																														
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																																														
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																														
S	2012	Colorado (First Gen)	Body	Base Radio																																																														
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																																														
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																														
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																														
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																														
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																														
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																														
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																														
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																														
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																														
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																														
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																														
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																														
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																														
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																														
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																														
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2012	Colorado (Second Gen)	Body	Body Control Module																																																														
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																														
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																														
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																														
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																														
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																														
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																														
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																														
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																														
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																														
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																														
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																														
S	2012	S10	Powertrain	Transfer Case Control Module																																																														
S	2012	S10	Chassis	Electronic Brake Control Module																																																														
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																														
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																														
S	2012	S10	Body	Body Control Module																																																														
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
S	2012	S10	Body	Instrument Cluster																																																														
S	2012	S10	Body	Trailer Interface Control Module																																																														
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																														
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																													
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																													
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																													
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																													
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																													
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																													
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																													
S	2013	Colorado	Powertrain	Transfer Case Control Module																																																													
S	2013	Colorado	Chassis	Electronic Brake Control Module																																																													
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																													
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																													
S	2013	Colorado	Body	Body Control Module																																																													
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2013	Colorado	Body	Instrument Cluster																																																													
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																													
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																													
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																													
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																													
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																													
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																													
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																													
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																													
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																													
S	2013	S10	Powertrain	Transfer Case Control Module																																																													
S	2013	S10	Chassis	Electronic Brake Control Module																																																													
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																													
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																													
S	2013	S10	Body	Body Control Module																																																													
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2013	S10	Body	Instrument Cluster																																																													
S	2013	S10	Body	Trailer Interface Control Module																																																													
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																													
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																													
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																													
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																													
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																													
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																													
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																													
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																													
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																													
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																													
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																													
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																													
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																													
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																													
S	2013	Trailblazer	Body	Body Control Module																																																													
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2013	Trailblazer	Body	Instrument Cluster																																																													
S	2013	Trailblazer	Body	Trailer Interface Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2013	Trailblazer	Body	Parking Assist Control Module																																																											
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																												
S	2014	Colorado	Powertrain	Transfer Case Control Module																																																													
S	2014	Colorado	Chassis	Electronic Brake Control Module																																																													
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																													
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2014	Colorado	Body	Body Control Module																																																												
S	2014	Colorado	Body	Body Control Module																																																												
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2014	Colorado	Body	Instrument Cluster																																																												
S	2014	Colorado	Body	Radio																																																												
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																																												
S	2014	Colorado	Body	Parking Assist Control Module																																																												
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2014	S10	Powertrain	Transfer Case Control Module																																																												
S	2014	S10	Chassis	Electronic Brake Control Module																																																												
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2014	S10	Body	Body Control Module																																																												
S	2014	S10	Body	Body Control Module																																																												
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
S	2014	S10	Body	Instrument Cluster																																																												
S	2014	S10	Body	Trailer Interface Control Module																																																												
S	2014	S10	Body	Radio																																																												
S	2014	S10	Body	Parking Assist Control Module																																																												
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																												
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																												
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																												
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																												
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																													
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																													
S	2014	Trailblazer	Body	Body Control Module																																																													
S	2014	Trailblazer	Body	Body Control Module																																																													
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2014	Trailblazer	Body	Instrument Cluster																																																													
S	2014	Trailblazer	Body	Trailer Interface Control Module																																																													
S	2014	Trailblazer	Body	Parking Assist Control Module																																																													
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																													
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																													
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																													
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																													
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																													
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																													
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																													
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
S	2015	Colorado	Powertrain	Chassis Control Module																																																													
S	2015	Colorado	Powertrain	Transfer Case Control Module																																																													
S	2015	Colorado	Chassis	Electronic Brake Control Module																																																													
S	2015	Colorado	Chassis	Power Steering Control Module																																																													
S	2015	Colorado	Body	Body Control Module																																																													
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2015	Colorado	Body	Passenger Presence Module																																																													
S	2015	Colorado	Body	Radio																																																													
S	2015	Colorado	Body	Amplifier																																																													
S	2015	Colorado	Body	Human Machine Interface Control Module																																																													
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																																													
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																													
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																													
S	2015	Colorado	Body	Frontview Camera Module																																																													
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																													
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																													
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																													
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																													
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																												
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																												
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																												
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																												
S	2015	Colorado (MMM)	Body	Body Control Module																																																												
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2015	Colorado (MMM)	Body	Instrument Cluster																																																													
S	2015	Colorado (MMM)	Body	Radio																																																														
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																														
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																														
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																														
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																														
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																														
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																														
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																														
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																														
S	2015	S10	Powertrain	Transfer Case Control Module																																																															
S	2015	S10	Chassis	Electronic Brake Control Module																																																															
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																															
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																															
S	2015	S10	Body	Body Control Module																																																															
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
S	2015	S10	Body	Instrument Cluster																																																															
S	2015	S10	Body	Trailer Interface Control Module																																																															
S	2015	S10	Body	Radio																																																															
S	2015	S10	Body	Telematics Communication Interface Control Module																																																															
S	2015	S10	Body	Parking Assist Control Module																																																															
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																															
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																															
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																															
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																															
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																															
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																															
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																															
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																															
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																															
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																															
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																															
S	2015	Trailblazer	Body	Body Control Module																																																															
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
S	2015	Trailblazer	Body	Instrument Cluster																																																															
S	2015	Trailblazer	Body	Trailer Interface Control Module																																																															
S	2015	Trailblazer	Body	Radio																																																															
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																															
S	2015	Trailblazer	Body	Parking Assist Control Module																																																															
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																															
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																															
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																															
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																															
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																															
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																															
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																																
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																																
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																																
S	2016	Colorado (1GC)	Body	Body Control Module																																																																
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																																																
S	2016	Colorado (1GC)	Body	Radio Controls																																																																
S	2016	Colorado (1GC)	Body	HVAC Controls																																																																
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																																
S	2016	Colorado (1GC)	Body	Radio																																																																
S	2016	Colorado (1GC)	Body	Amplifier																																																																
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																																
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																																
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																																
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																																
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																																
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																																																
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																																
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																																
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																																
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																																
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																																
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																																
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																																
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																																
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																																
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																																
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																																
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																																
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																																
S	2016	Colorado (MMM)	Body	Body Control Module																																																																
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
S	2016	Colorado (MMM)	Body	Instrument Cluster																																																																
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																																
S	2016	Colorado (MMM)	Body	Radio																																																																
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																																
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																																
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																																
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																																
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																																
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																																
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																																
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																																
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																																
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																																
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																																
S	2016	S10	Powertrain	Transfer Case Control Module																																																																
S	2016	S10	Chassis	Electronic Brake Control Module																																																																
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																																
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																																
S	2016	S10	Body	Body Control Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
S	2016	S10	Body	Instrument Cluster																																																															
S	2016	S10	Body	Trailer Interface Control Module																																																															
S	2016	S10	Body	Radio																																																															
S	2016	S10	Body	Telematics Communication Interface Control Module																																																															
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																															
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																															
S	2016	S10	Body	Parking Assist Control Module																																																															
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																															
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																															
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																															
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																															
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																															
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																															
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																															
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																															
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																															
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																															
S	2016	Trailblazer	Body	Body Control Module																																																															
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
S	2016	Trailblazer	Body	Instrument Cluster																																																															
S	2016	Trailblazer	Body	Trailer Interface Control Module																																																															
S	2016	Trailblazer	Body	Radio																																																															
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																															
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																															
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																															
S	2016	Trailblazer	Body	Parking Assist Control Module																																																															
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																															
T	2004	S10	Chassis	4WAL 3 Sensor																																																															
T	2004	S10	Chassis	Traction Assist (If Equipped)																																																															
T	2004	S10	Body	Body Control Module																																																															
T	2004	S10	Body	Instrument Panel Cluster																																																															
T	2004	S10	Body	Base Radio																																																															
T	2004	S10	Body	Uplevel Radio																																																															
T	2004	S10	Body	Supplemental Inflatable Restraint																																																															
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																															
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																															
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																															
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																															
T	2004	Colorado	Chassis	ABS Without Traction Control																																																															
T	2004	Colorado	Chassis	ABS With Traction Control																																																															
T	2004	Colorado	Body	Body Control Module																																																															
T	2004	Colorado	Body	Instrument Panel Cluster																																																															
T	2004	Colorado	Body	OnStar																																																															
T	2004	Colorado	Body	Base Radio																																																															
T	2004	Colorado	Body	Uplevel Radio																																																															
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																																															
T	2004	Colorado	Body	Instrument Panel Cluster																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																												V																	
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																												V																	
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																																												
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																												
T	2004	TrailBlazer	Body	Amplifier (Bose)																																																												
T	2004	TrailBlazer	Body	Body Control Module																																																												
T	2004	TrailBlazer	Body	Driver Door Module																																																												
T	2004	TrailBlazer	Body	Driver Seat Module																																																												
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto																																																												
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																																												
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																																												
T	2004	TrailBlazer	Body	Lift Gate Module																																																												
T	2004	TrailBlazer	Body	OnStar																																																												
T	2004	TrailBlazer	Body	Passenger Door Module																																																												
T	2004	TrailBlazer	Body	Uplevel Radio																																																												
T	2004	TrailBlazer	Body	Navigation Radio																																																												
T	2004	TrailBlazer	Body	Rear Seat Audio																																																												
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																																												
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																																												
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																																												
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																												V																	
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																												
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																												
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																												V																	
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																												
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																												
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																																												
T	2004	TrailBlazer EXT	Body	Body Control Module																																																												
T	2004	TrailBlazer EXT	Body	Driver Door Module																																																												
T	2004	TrailBlazer EXT	Body	Driver Seat Module																																																												
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																												
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																												
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																																												
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																																												
T	2004	TrailBlazer EXT	Body	OnStar																																																												
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																																												
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																																												
T	2004	TrailBlazer EXT	Body	Navigation Radio																																																												
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																												
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																																												
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																																												
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																												
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																												
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																													
T	2004	Blazer	Chassis	4WAL 3 Sensor																																																														
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																																														
T	2004	Blazer	Body	Body Control Module																																																				V	V	V	V								
T	2004	Blazer	Body	Heating and Air Conditioning																																																														
T	2004	Blazer	Body	Instrument Panel Cluster																																																														
T	2004	Blazer	Body	Memory Seat Module																																																														
T	2004	Blazer	Body	Base Radio																																																														
T	2004	Blazer	Body	Uplevel Radio																																																														
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																																														
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																														
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																														
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																														
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																														
T	2005	Colorado	Chassis	ABS Without Traction Control																																																														
T	2005	Colorado	Chassis	ABS With Traction Control																																																														
T	2005	Colorado	Body	Body Control Module																																																						V									
T	2005	Colorado	Body	Instrument Panel Cluster																																																														
T	2005	Colorado	Body	Base Radio																																																														
T	2005	Colorado	Body	Uplevel Radio																																																														
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																																														
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																																														
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																					V									
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																														
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																																														
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																																														
T	2005	TrailBlazer	Body	Body Control Module																																																														
T	2005	TrailBlazer	Body	Disc Player and Video Display																																																														
T	2005	TrailBlazer	Body	Driver Door Module																																																														
T	2005	TrailBlazer	Body	Driver Seat Module																																																														
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto																																																														
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																																														
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																																														
T	2005	TrailBlazer	Body	Lift Gate Module																																																														
T	2005	TrailBlazer	Body	Passenger Door Module																																																														
T	2005	TrailBlazer	Body	Passenger Presence System																																																														
T	2005	TrailBlazer	Body	Uplevel Radio																																																														
T	2005	TrailBlazer	Body	Navigation Radio																																																														
T	2005	TrailBlazer	Body	Rear Seat Audio																																																														
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																																														
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																																														
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																																														
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																						V									
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																					V									

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																																																
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																																
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																																																
T	2005	TrailBlazer EXT	Body	Body Control Module																																																																
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																																																
T	2005	TrailBlazer EXT	Body	Driver Door Module																																																																
T	2005	TrailBlazer EXT	Body	Driver Seat Module																																																																
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																																
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																																
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																																																
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																																																
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																																																
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																																																
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																																																
T	2005	TrailBlazer EXT	Body	Navigation Radio																																																																
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																																
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																																																
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																																																
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																																
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																																
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																																
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																																
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																																
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																																
T	2005	Blazer	Chassis	4WAL 3 Sensor																																																																
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																																																
T	2005	Blazer	Body	Body Control Module																																																					V	V	V	V								
T	2005	Blazer	Body	Heating and Air Conditioning																																																																
T	2005	Blazer	Body	Instrument Panel Cluster																																																																
T	2005	Blazer	Body	Memory Seat Module																																																																
T	2005	Blazer	Body	Base Radio																																																																
T	2005	Blazer	Body	Uplevel Radio																																																																
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																																																
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																																
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																																
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																																
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																																
T	2006	Colorado	Chassis	ABS Without Traction Control																																																																
T	2006	Colorado	Chassis	ABS With Traction Control																																																																
T	2006	Colorado	Body	Body Control Module																																																							V									
T	2006	Colorado	Body	Instrument Panel Cluster																																																																
T	2006	Colorado	Body	Passenger Presence System																																																																
T	2006	Colorado	Body	Base Radio																																																																
T	2006	Colorado	Body	Uplevel Radio																																																																
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																																																
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																																																
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																																
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																																
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																												V																				
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																																
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																										V															
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																																									
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																																									
T	2006	TrailBlazer	Body	Body Control Module																																																									
T	2006	TrailBlazer	Body	Disc Player and Video Display																																																									
T	2006	TrailBlazer	Body	Driver Door Module																																																									
T	2006	TrailBlazer	Body	Driver Seat Module																																																									
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto																																																									
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																																									
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																																									
T	2006	TrailBlazer	Body	Lift Gate Module																																																									
T	2006	TrailBlazer	Body	Passenger Door Module																																																									
T	2006	TrailBlazer	Body	Passenger Presence System																																																									
T	2006	TrailBlazer	Body	Uplevel Radio																																																									
T	2006	TrailBlazer	Body	Navigation Radio																																																									
T	2006	TrailBlazer	Body	Rear Seat Audio																																																									
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																																									
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																																									
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																																									
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																										V															
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																										V															
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																																									
T	2006	TrailBlazer EXT	Body	Body Control Module																																																									
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																																									
T	2006	TrailBlazer EXT	Body	Driver Door Module																																																									
T	2006	TrailBlazer EXT	Body	Driver Seat Module																																																									
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto																																																									
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																																									
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																																									
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																																									
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																																									
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																																									
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																																									
T	2006	TrailBlazer EXT	Body	Navigation Radio																																																									
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																																									
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																																									
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																																									
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																																									
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																																									
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																																									
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																									
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																																													
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																																													
T	2007	Colorado	Body	Body Control Module																																																				V									
T	2007	Colorado	Body	Digital Radio Receiver																																																													
T	2007	Colorado	Body	Generator Battery Control Module																																																													
T	2007	Colorado	Body	Instrument Panel Cluster																																																													
T	2007	Colorado	Body	Passenger Presence System																																																													
T	2007	Colorado	Body	Base Radio																																																													
T	2007	Colorado	Body	Uplevel Radio																																																													
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																																													
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																																													
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																													
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																													
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																													
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																													
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																													
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																													
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																													
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																													
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																																														
T	2007	Trailblazer	Body	Body Control Module																																																														
T	2007	Trailblazer	Body	Digital Radio Receiver																																																														
T	2007	Trailblazer	Body	Disc Player and Video Display																																																														
T	2007	Trailblazer	Body	Driver Door Module																																																														
T	2007	Trailblazer	Body	Driver Seat Module																																																														
T	2007	Trailblazer	Body	Generator Battery Control Module																																																														
T	2007	Trailblazer	Body	HVAC Control Module Auto																																																														
T	2007	Trailblazer	Body	HVAC Control Module Manual																																																														
T	2007	Trailblazer	Body	Instrument Panel Cluster																																																														
T	2007	Trailblazer	Body	Lift Gate Module																																																														
T	2007	Trailblazer	Body	Passenger Door Module																																																														
T	2007	Trailblazer	Body	Passenger Presence System																																																														
T	2007	Trailblazer	Body	Uplevel Radio																																																														
T	2007	Trailblazer	Body	Navigation Radio																																																														
T	2007	Trailblazer	Body	Rear Seat Audio																																																														
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																																														
T	2007	Trailblazer	Body	Theft Deterrent Module																																																														
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																																														
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																														
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																														
T	2008	Colorado	Chassis	Electronic Brake Control Module																																																														
T	2008	Colorado	Body	Body Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2008	Colorado	Body	Digital Radio Receiver																																																														
T	2008	Colorado	Body	Generator Battery Control Module																																																															
T	2008	Colorado	Body	Instrument Panel Cluster																																																															
T	2008	Colorado	Body	Passenger Presence System																																																															
T	2008	Colorado	Body	Base Radio																																																															
T	2008	Colorado	Body	Uplevel Radio																																																															
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																																															
T	2008	Colorado	Body	Theft Deterrent Module																																																															
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																																															
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																															
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																															
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																																															
T	2008	TrailBlazer	Body	Body Control Module																																																															
T	2008	TrailBlazer	Body	Digital Radio Receiver																																																															
T	2008	TrailBlazer	Body	Disc Player and Video Display																																																															
T	2008	TrailBlazer	Body	Driver Door Module																																																															
T	2008	TrailBlazer	Body	Driver Seat Module																																																															
T	2008	TrailBlazer	Body	Generator Battery Control Module																																																															
T	2008	TrailBlazer	Body	HVAC Control Module Auto																																																															
T	2008	TrailBlazer	Body	HVAC Control Module Manual																																																															
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																																															
T	2008	TrailBlazer	Body	Lift Gate Module																																																															
T	2008	TrailBlazer	Body	Passenger Door Module																																																															
T	2008	TrailBlazer	Body	Passenger Presence System																																																															
T	2008	TrailBlazer	Body	Uplevel Radio																																																															
T	2008	TrailBlazer	Body	Navigation Radio																																																															
T	2008	TrailBlazer	Body	Rear Seat Audio																																																															
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																																															
T	2008	TrailBlazer	Body	Theft Deterrent Module																																																															
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																																															
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																															
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																															
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																															
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																															
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																															
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																															
T	2009	Colorado	Chassis	Electronic Brake Control Module																																																															
T	2009	Colorado	Body	Body Control Module																																																															
T	2009	Colorado	Body	Digital Radio Receiver																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2009	Colorado	Body	Generator Battery Control Module																																																															
T	2009	Colorado	Body	Instrument Panel Cluster																																																															
T	2009	Colorado	Body	Passenger Presence System																																																															
T	2009	Colorado	Body	Base Radio																																																															
T	2009	Colorado	Body	Uplevel Radio																																																															
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																																															
T	2009	Colorado	Body	Theft Deterrent Module																																																															
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																															
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																															
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																																															
T	2009	TrailBlazer	Body	Body Control Module																																																															
T	2009	TrailBlazer	Body	Digital Radio Receiver																																																															
T	2009	TrailBlazer	Body	Disc Player and Video Display																																																															
T	2009	TrailBlazer	Body	Driver Door Module																																																															
T	2009	TrailBlazer	Body	Driver Seat Module																																																															
T	2009	TrailBlazer	Body	Generator Battery Control Module																																																															
T	2009	TrailBlazer	Body	HVAC Control Module Auto																																																															
T	2009	TrailBlazer	Body	HVAC Control Module Manual																																																															
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																																															
T	2009	TrailBlazer	Body	Lift Gate Module																																																															
T	2009	TrailBlazer	Body	Passenger Door Module																																																															
T	2009	TrailBlazer	Body	Passenger Presence System																																																															
T	2009	TrailBlazer	Body	Uplevel Radio																																																															
T	2009	TrailBlazer	Body	Navigation Radio																																																															
T	2009	TrailBlazer	Body	Rear Seat Audio																																																															
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																																															
T	2009	TrailBlazer	Body	Theft Deterrent Module																																																															
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																															
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																															
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																															
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																															
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																															
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																															
T	2010	ALL	Chassis	Electronic Brake Control Module																																																															
T	2010	ALL	Body	Body Control Module																																																															
T	2010	ALL	Body	Digital Radio Receiver																																																															
T	2010	ALL	Body	Generator Battery Control Module																																																															
T	2010	ALL	Body	Instrument Panel Cluster																																																															
T	2010	ALL	Body	Passenger Presence System																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2010	ALL	Body	Personal Audio Link Module																																																											
T	2010	ALL	Body	Base Radio																																																											
T	2010	ALL	Body	Uplevel Radio																																																											
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2010	ALL	Body	Theft Deterrent Module																																																											
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																											
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
T	2011	ALL	Chassis	Electronic Brake Control Module																																																											
T	2011	ALL	Body	Body Control Module																																																				V								
T	2011	ALL	Body	Digital Radio Receiver																																																											
T	2011	ALL	Body	Generator Battery Control Module																																																											
T	2011	ALL	Body	Instrument Panel Cluster																																																											
T	2011	ALL	Body	Passenger Presence System																																																											
T	2011	ALL	Body	Personal Audio Link Module																																																											
T	2011	ALL	Body	Base Radio																																																											
T	2011	ALL	Body	Uplevel Radio																																																											
T	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
T	2011	ALL	Body	Theft Deterrent Module																																																											
T	2011	ALL	Body	Vehicle Comm. Interface Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																																											
T	2012	Colorado (First Gen)	Body	Body Control Module																																																				V								
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																																											
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																																											
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																																											
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																																											
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																																											
T	2012	Colorado (First Gen)	Body	Base Radio																																																											
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																																											
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																																												
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																																												
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																																												
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																																												
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																																												
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																																												
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2012	Colorado (Second Gen)	Body	Body Control Module																																																													
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																																												
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																																												
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																												
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																												
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																																												
T	2012	S10	Powertrain	Transfer Case Control Module																																																												
T	2012	S10	Chassis	Electronic Brake Control Module																																																												
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																																												
T	2012	S10	Body	Body Control Module																																																												
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
T	2012	S10	Body	Instrument Cluster																																																												
T	2012	S10	Body	Trailer Interface Control Module																																																												
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																												
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																												
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																												
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																												
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																												
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																												
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																																												
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																												
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																												
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																												
T	2013	Colorado	Powertrain	Transfer Case Control Module																																																												
T	2013	Colorado	Chassis	Electronic Brake Control Module																																																												
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																												
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2013	Colorado	Body	Body Control Module																																																																
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																	
T	2013	Colorado	Body	Instrument Cluster																																																																	
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																																	
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																																	
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																																	
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																																	
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																																	
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																																	
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																																	
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																																	
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																																																	
T	2013	S10	Powertrain	Transfer Case Control Module																																																																	
T	2013	S10	Chassis	Electronic Brake Control Module																																																																	
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																																	
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																																																	
T	2013	S10	Body	Body Control Module																																																																	
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																	
T	2013	S10	Body	Instrument Cluster																																																																	
T	2013	S10	Body	Trailer Interface Control Module																																																																	
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																																																	
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																																																	
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																																																	
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																																																	
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																																																	
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																																	
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																																	
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																																	
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																																	
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																																	
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																																	
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																																																	
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																																																	
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																																	
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																																	
T	2013	Trailblazer	Body	Body Control Module																																																																	
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																	
T	2013	Trailblazer	Body	Instrument Cluster																																																																	
T	2013	Trailblazer	Body	Trailer Interface Control Module																																																																	
T	2013	Trailblazer	Body	Parking Assist Control Module																																																																	
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																																	
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																																	
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																																	
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																																	
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																																	
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																																	
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																																	
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																																	
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																																	
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																																																	
T	2014	Colorado	Powertrain	Transfer Case Control Module																																																																	

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2014	Colorado	Chassis	Electronic Brake Control Module																																																												
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2014	Colorado	Body	Body Control Module																																																													
T	2014	Colorado	Body	Body Control Module																																																													
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2014	Colorado	Body	Instrument Cluster																																																													
T	2014	Colorado	Body	Radio																																																													
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																																													
T	2014	Colorado	Body	Parking Assist Control Module																																																													
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																																													
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																																													
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																													
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																													
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																													
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																													
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																													
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																													
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																																													
T	2014	S10	Powertrain	Transfer Case Control Module																																																													
T	2014	S10	Chassis	Electronic Brake Control Module																																																													
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2014	S10	Body	Body Control Module																																																													
T	2014	S10	Body	Body Control Module																																																													
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2014	S10	Body	Instrument Cluster																																																													
T	2014	S10	Body	Trailer Interface Control Module																																																													
T	2014	S10	Body	Radio																																																													
T	2014	S10	Body	Parking Assist Control Module																																																													
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																													
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																													
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																													
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																													
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																													
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																																													
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																																													
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																																													
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																																													
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																																													
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2014	Trailblazer	Body	Body Control Module																																																													
T	2014	Trailblazer	Body	Body Control Module																																																													
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2014	Trailblazer	Body	Instrument Cluster																																																													
T	2014	Trailblazer	Body	Trailer Interface Control Module																																																													
T	2014	Trailblazer	Body	Parking Assist Control Module																																																													
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																													
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																														
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																														
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																														
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																																														
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																														
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																														
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
T	2015	Colorado	Powertrain	Chassis Control Module																																																															
T	2015	Colorado	Powertrain	Transfer Case Control Module																																																															
T	2015	Colorado	Chassis	Electronic Brake Control Module																																																															
T	2015	Colorado	Chassis	Power Steering Control Module																																																															
T	2015	Colorado	Body	Body Control Module																																																															
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
T	2015	Colorado	Body	Passenger Presence Module																																																															
T	2015	Colorado	Body	Radio																																																															
T	2015	Colorado	Body	Amplifier																																																															
T	2015	Colorado	Body	Human Machine Interface Control Module																																																															
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																																															
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																																															
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																																															
T	2015	Colorado	Body	Frontview Camera Module																																																															
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																															
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																															
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																															
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																															
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																															
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																															
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																															
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																																															
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																															
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																															
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																															
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																															
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																															
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																															
T	2015	Colorado (MMM)	Body	Body Control Module																																																															
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
T	2015	Colorado (MMM)	Body	Instrument Cluster																																																															
T	2015	Colorado (MMM)	Body	Radio																																																															
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																															
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																																															
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																																															
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																																															
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																															
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																															
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																															
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																															
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																															
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																										
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2015	S10	Powertrain	Transfer Case Control Module																																																											
T	2015	S10	Chassis	Electronic Brake Control Module																																																											
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2015	S10	Body	Body Control Module																																																											
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2015	S10	Body	Instrument Cluster																																																											
T	2015	S10	Body	Trailer Interface Control Module																																																											
T	2015	S10	Body	Radio																																																											
T	2015	S10	Body	Telematics Communication Interface Control Module																																																											
T	2015	S10	Body	Parking Assist Control Module																																																											
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																											
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																											
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																																											
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																																											
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																																											
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																																											
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																																											
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2015	Trailblazer	Body	Body Control Module																																																											
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2015	Trailblazer	Body	Instrument Cluster																																																											
T	2015	Trailblazer	Body	Trailer Interface Control Module																																																											
T	2015	Trailblazer	Body	Radio																																																										
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																																											
T	2015	Trailblazer	Body	Parking Assist Control Module																																																											
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																																											
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																																											
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																																											
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																																											
T	2016	Colorado (1GC)	Body	Body Control Module																																																											
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																																											
T	2016	Colorado (1GC)	Body	Radio Controls																																																											
T	2016	Colorado (1GC)	Body	HVAC Controls																																																											
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																																											
T	2016	Colorado (1GC)	Body	Radio																																																											
T	2016	Colorado (1GC)	Body	Amplifier																																																											
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																																													
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																																													
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																																													
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																																													
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																																													
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																													
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																													
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																													
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																													
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																																													
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																																													
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																																													
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2016	Colorado (MMM)	Body	Body Control Module																																																													
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2016	Colorado (MMM)	Body	Instrument Cluster																																																													
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																																													
T	2016	Colorado (MMM)	Body	Radio																																																													
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																																													
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																																													
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																																													
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																																													
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																																													
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																													
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																													
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																																													
T	2016	S10	Powertrain	Transfer Case Control Module																																																													
T	2016	S10	Chassis	Electronic Brake Control Module																																																													
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																																													
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																																													
T	2016	S10	Body	Body Control Module																																																													
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
T	2016	S10	Body	Instrument Cluster																																																													
T	2016	S10	Body	Trailer Interface Control Module																																																													
T	2016	S10	Body	Radio																																																												
T	2016	S10	Body	Telematics Communication Interface Control Module																																																													
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																																												
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																																												
T	2016	S10	Body	Parking Assist Control Module																																																												
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																																												
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																																												
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																																												
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																																											
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																																											
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																																											
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																																											
T	2016	Trailblazer	Body	Body Control Module																																																											
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
T	2016	Trailblazer	Body	Instrument Cluster																																																											
T	2016	Trailblazer	Body	Trailer Interface Control Module																																																											
T	2016	Trailblazer	Body	Radio																																																											
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																																											
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																																											
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																																											
T	2016	Trailblazer	Body	Parking Assist Control Module																																																											
V	2009	ALL	Powertrain	Engine Control Module																																																											
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2009	ALL	Powertrain	Rear Drive System																																																											
V	2009	ALL	Powertrain	Transmission Control Module																																																											
V	2009	ALL	Chassis	Electronic Brake Control Module																																																											
V	2009	ALL	Body	Body Control Module																																																											
V	2009	ALL	Body	Digital Radio Receiver																																																											
V	2009	ALL	Body	Driver Door Switch																																																											
V	2009	ALL	Body	Heated Seat Module																																																											
V	2009	ALL	Body	HVAC Control Module Auto																																																											
V	2009	ALL	Body	HVAC Control Module Manual																																																											
V	2009	ALL	Body	Instrument Panel Cluster																																																											
V	2009	ALL	Body	Lift Gate Module																																																											
V	2009	ALL	Body	Park Assist Module																																																											
V	2009	ALL	Body	Passenger Door Switch																																																											
V	2009	ALL	Body	Passenger Presence System																																																											
V	2009	ALL	Body	Radio																																																											
V	2009	ALL	Body	Rear HVAC/RSA																																																											
V	2009	ALL	Body	Rollover Sensor																																																											
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2009	ALL	Body	Theft Deterrent Module																																																											
V	2010	ALL	Powertrain	Engine Control Module																																																											
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2010	ALL	Powertrain	Rear Drive System																																																											
V	2010	ALL	Powertrain	Transmission Control Module																																																											
V	2010	ALL	Chassis	Electronic Brake Control Module																																																											
V	2010	ALL	Body	Body Control Module																																																											
V	2010	ALL	Body	Digital Radio Receiver																																																											
V	2010	ALL	Body	Driver Door Switch																																																											
V	2010	ALL	Body	Heated Seat Module																																																											
V	2010	ALL	Body	HVAC Control Module Auto																																																											
V	2010	ALL	Body	HVAC Control Module Manual																																																											
V	2010	ALL	Body	Instrument Panel Cluster																																																											
V	2010	ALL	Body	Lift Gate Module																																																											
V	2010	ALL	Body	Park Assist Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
V	2010	ALL	Body	Passenger Door Switch																																																											
V	2010	ALL	Body	Passenger Presence System																																																												
V	2010	ALL	Body	Radio																																																												
V	2010	ALL	Body	Rear HVAC/RSA																																																												
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2010	ALL	Body	Theft Deterrent Module																																																												
V	2011	ALL	Powertrain	Engine Control Module																																																												
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2011	ALL	Powertrain	Rear Drive System																																																												
V	2011	ALL	Powertrain	Transmission Control Module																																																												
V	2011	ALL	Chassis	Electronic Brake Control Module																																																												
V	2011	ALL	Body	Body Control Module																																																												
V	2011	ALL	Body	Digital Radio Receiver																																																												
V	2011	ALL	Body	Driver Door Switch																																																												
V	2011	ALL	Body	Heated Seat Module																																																												
V	2011	ALL	Body	HVAC Control Module Auto																																																												
V	2011	ALL	Body	HVAC Control Module Manual																																																												
V	2011	ALL	Body	Instrument Panel Cluster																																																												
V	2011	ALL	Body	Lift Gate Module																																																												
V	2011	ALL	Body	Park Assist Module																																																												
V	2011	ALL	Body	Passenger Door Switch																																																												
V	2011	ALL	Body	Passenger Presence System																																																												
V	2011	ALL	Body	Radio																																																												
V	2011	ALL	Body	Rear HVAC/RSA																																																												
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2011	ALL	Body	Theft Deterrent Module																																																												
V	2012	ALL	Powertrain	Engine Control Module																																																												
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2012	ALL	Powertrain	Rear Drive System																																																												
V	2012	ALL	Powertrain	Transmission Control Module																																																												
V	2012	ALL	Chassis	Electronic Brake Control Module																																																												
V	2012	ALL	Body	Body Control Module																																																												
V	2012	ALL	Body	Digital Radio Receiver																																																												
V	2012	ALL	Body	Driver Door Switch																																																												
V	2012	ALL	Body	Heated Seat Module																																																												
V	2012	ALL	Body	HVAC Control Module Auto																																																												
V	2012	ALL	Body	HVAC Control Module Manual																																																												
V	2012	ALL	Body	Instrument Panel Cluster																																																												
V	2012	ALL	Body	Lift Gate Module																																																												
V	2012	ALL	Body	Park Assist Module																																																												
V	2012	ALL	Body	Passenger Door Switch																																																												
V	2012	ALL	Body	Passenger Presence System																																																												
V	2012	ALL	Body	Radio																																																												
V	2012	ALL	Body	Rear HVAC/RSA																																																												
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2012	ALL	Body	Theft Deterrent Module																																																												
V	2013	ALL	Powertrain	Engine Control Module																																																												
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2013	ALL	Powertrain	Rear Drive System																																																												
V	2013	ALL	Powertrain	Transmission Control Module																																																												
V	2013	ALL	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
V	2013	ALL	Body	Body Control Module																																																											
V	2013	ALL	Body	Digital Radio Receiver																																																												
V	2013	ALL	Body	Driver Door Switch																																																												
V	2013	ALL	Body	Heated Seat Module																																																												
V	2013	ALL	Body	HVAC Control Module Auto																																																												
V	2013	ALL	Body	HVAC Control Module Manual																																																												
V	2013	ALL	Body	Instrument Panel Cluster																																																												
V	2013	ALL	Body	Left Side Object Detection Module																																																												
V	2013	ALL	Body	Lift Gate Module																																																												
V	2013	ALL	Body	Park Assist Module																																																												
V	2013	ALL	Body	Passenger Door Switch																																																												
V	2013	ALL	Body	Passenger Presence System																																																												
V	2013	ALL	Body	Radio																																																												
V	2013	ALL	Body	Rear HVAC/RSA																																																												
V	2013	ALL	Body	Right Side Object Detection Module																																																												
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2013	ALL	Body	Theft Deterrent Module																																																												
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2014	Traverse	Powertrain	Chassis Control Module																																																												
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
V	2014	Traverse	Chassis	Electronic Brake Control Module																																																												
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																																												
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																												
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2014	Traverse	Body	Passenger Presence Module																																																												
V	2014	Traverse	Body	Instrument Cluster																																																												
V	2014	Traverse	Body	Radio																																																												
V	2014	Traverse	Body	Rear Audio Control Module																																																												
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																																												
V	2014	Traverse	Body	Personal Audio Link Control Module																																																												
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																												
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																																												
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																																												
V	2014	Traverse	Body	Liftgate Control Module																																																												
V	2014	Traverse	Body	Seat Memory Control Module																																																												
V	2014	Traverse	Body	Front Seat Heating Control Module																																																												
V	2014	Traverse	Body	Right Side Object Detection Control Module																																																												
V	2014	Traverse	Body	Left Side Object Detection Control Module																																																												
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																																												
V	2014	Traverse	Body	Parking Assist Control Module																																																												
V	2014	Traverse	Body	Frontview Camera Module																																																												
V	2014	Traverse	Body	Theft Deterrent Module																																																												
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
V	2015	Traverse	Chassis	Electronic Brake Control Module																																																												
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																											
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2015	Traverse	Body	Passenger Presence Module																																																												
V	2015	Traverse	Body	Instrument Cluster																																																												
V	2015	Traverse	Body	Radio																																																												
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																																												
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																												
V	2015	Traverse	Body	Liftgate Control Module																																																												
V	2015	Traverse	Body	Seat Memory Control Module																																																												
V	2015	Traverse	Body	Front Seat Heating Control Module																																																												
V	2015	Traverse	Body	Right Side Object Detection Control Module																																																												
V	2015	Traverse	Body	Left Side Object Detection Control Module																																																												
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																																												
V	2015	Traverse	Body	Parking Assist Control Module																																																												
V	2015	Traverse	Body	Frontview Camera Module																																																												
V	2015	Traverse	Body	Theft Deterrent Module																																																												
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																																												
V	2016	Traverse	Chassis	Electronic Brake Control Module																																																												
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																																												
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																																												
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2016	Traverse	Body	Passenger Presence Module																																																												
V	2016	Traverse	Body	Instrument Cluster																																																												
V	2016	Traverse	Body	Radio																																																											
V	2016	Traverse	Body	Rear Audio Control Module																																																											
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																																											
V	2016	Traverse	Body	Personal Audio Link Control Module																																																											
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																																											
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																																											
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																																											
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																																											
V	2016	Traverse	Body	Liftgate Control Module																																																											
V	2016	Traverse	Body	Seat Memory Control Module																																																											
V	2016	Traverse	Body	Front Seat Heating Control Module																																																											
V	2016	Traverse	Body	Right Side Object Detection Control Module																																																											
V	2016	Traverse	Body	Left Side Object Detection Control Module																																																											
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																																											
V	2016	Traverse	Body	Parking Assist Control Module																																																											
V	2016	Traverse	Body	Frontview Camera Module																																																											
V	2016	Traverse	Body	Theft Deterrent Module																																																											
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																											
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																											
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																											
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																											
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																													
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																																														
A	2011	Orlando	Chassis	Electronic Brake Control Module																																																														
A	2011	Orlando	Chassis	Parking Brake Control Module																																																														
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																														
A	2011	Orlando	Chassis	Power Steering Control Module																																																														
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																														
A	2011	Orlando	Body	Body Control Module																																																														
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
A	2011	Orlando	Body	Instrument Cluster																																																														
A	2011	Orlando	Body	Trailer Interface Control Module																																																														
A	2011	Orlando	Body	Radio																																																														
A	2011	Orlando	Body	Multimedia Player Interface Module																																																														
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																														
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																														
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																														
A	2011	Orlando	Body	Keyless Entry Control Module																																																														
A	2011	Orlando	Body	Parking Assist Control Module																																																														
A	2011	Orlando	Body	Steering Column Lock Control Module																																																														
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																														
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																														
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																														
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																														
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																														
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																														
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																														
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																														
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																														
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																																														
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																																														
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																																														
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																																														
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																																														
A	2012	Orlando	Chassis	Electronic Brake Control Module																																																														
A	2012	Orlando	Chassis	Parking Brake Control Module																																																														
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																														
A	2012	Orlando	Chassis	Power Steering Control Module																																																														
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																														
A	2012	Orlando	Body	Body Control Module																																																														
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
A	2012	Orlando	Body	Instrument Cluster																																																														
A	2012	Orlando	Body	Trailer Interface Control Module																																																														
A	2012	Orlando	Body	Radio																																																														
A	2012	Orlando	Body	Multimedia Player Interface Module																																																														
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																														
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																														
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																																														
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																																														
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																																														
A	2012	Orlando	Body	Keyless Entry Control Module																																																														
A	2012	Orlando	Body	Parking Assist Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
A	2012	Orlando	Body	Steering Column Lock Control Module																																																											
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																												
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																												
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																												
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																												
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																												
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																												
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																												
A	2013	Orlando	Chassis	Electronic Brake Control Module																																																												
A	2013	Orlando	Chassis	Parking Brake Control Module																																																												
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
A	2013	Orlando	Chassis	Power Steering Control Module																																																												
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												
A	2013	Orlando	Body	Body Control Module																																																												
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
A	2013	Orlando	Body	Instrument Cluster																																																												
A	2013	Orlando	Body	Radio																																																												
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																																												
A	2013	Orlando	Body	Multimedia Player Interface Module																																																												
A	2013	Orlando	Body	Mobile Telephone Control Module																																																												
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																												
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																												
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																												
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																												
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																												
A	2013	Orlando	Body	Front Seat Heating Control Module																																																												
A	2013	Orlando	Body	Keyless Entry Control Module																																																												
A	2013	Orlando	Body	Parking Assist Control Module																																																												
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																												
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																												
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																												
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																												
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																												
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																												
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																												
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																												
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																												
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																												
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																													
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																													
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																													
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																																													
A	2014	Orlando	Chassis	Electronic Brake Control Module																																																													
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																													
A	2014	Orlando	Chassis	Power Steering Control Module																																																													
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2014	Orlando	Body	Body Control Module																																																													
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2014	Orlando	Body	Instrument Cluster																																																													
A	2014	Orlando	Body	Radio																																																													
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																																													
A	2014	Orlando	Body	Multimedia Player Interface Module																																																													
A	2014	Orlando	Body	Mobile Telephone Control Module																																																													
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																													
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																													
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																													
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																													
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																													
A	2014	Orlando	Body	Front Seat Heating Control Module																																																													
A	2014	Orlando	Body	Rear Seat Heating Control Module																																																													
A	2014	Orlando	Body	Keyless Entry Control Module																																																													
A	2014	Orlando	Body	Parking Assist Control Module																																																													
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																													
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																													
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																													
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																													
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																													
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																													
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																													
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																													
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																													
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																													
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																													
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																																													
A	2015	Orlando	Chassis	Electronic Brake Control Module																																																													
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																													
A	2015	Orlando	Chassis	Power Steering Control Module																																																													
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																													
A	2015	Orlando	Body	Body Control Module																																																													
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
A	2015	Orlando	Body	Instrument Cluster																																																													
A	2015	Orlando	Body	Radio																																																													
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																																													
A	2015	Orlando	Body	Mobile Telephone Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																																														
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																														
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																														
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																														
A	2015	Orlando	Body	Front Seat Heating Control Module																																																														
A	2015	Orlando	Body	Rear Seat Heating Control Module																																																														
A	2015	Orlando	Body	Keyless Entry Control Module																																																														
A	2015	Orlando	Body	Parking Assist Control Module																																																														
A	2015	Orlando	Body	Frontview Camera Module																																																														
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																														
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																														
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																														
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																														
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																														
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																														
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																														
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																														
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																														
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																														
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																														
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																														
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																														
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																														
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																																														
A	2016	Orlando	Chassis	Electronic Brake Control Module																																																														
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																														
A	2016	Orlando	Chassis	Power Steering Control Module																																																														
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																														
A	2016	Orlando	Body	Body Control Module																																																														
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
A	2016	Orlando	Body	Instrument Cluster																																																														
A	2016	Orlando	Body	Radio																																																														
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																																														
A	2016	Orlando	Body	Multimedia Player Interface Module																																																														
A	2016	Orlando	Body	Mobile Telephone Control Module																																																														
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																																														
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																														
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																														
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																														
A	2016	Orlando	Body	Front Seat Heating Control Module																																																														
A	2016	Orlando	Body	Rear Seat Heating Control Module																																																														
A	2016	Orlando	Body	Keyless Entry Control Module																																																														
A	2016	Orlando	Body	Parking Assist Control Module																																																														
A	2016	Orlando	Body	Frontview Camera Module																																																														
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																																																														
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																																																														
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																																																														
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																																																														
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																																																															
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																															
C	2009	N200	Chassis	Electronic Brake Control Module																																																															
C	2009	N200	Body	Supplemental Inflatable Restraint																																																															
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																															
C	2009	N300	Chassis	Electronic Brake Control Module																																																															
C	2009	N300	Body	Supplemental Inflatable Restraint																																																															
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																															
C	2010	N200	Chassis	Electronic Brake Control Module																																																															
C	2010	N200	Body	Supplemental Inflatable Restraint																																																															
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																															
C	2010	N300	Chassis	Electronic Brake Control Module																																																															
C	2010	N300	Body	Supplemental Inflatable Restraint																																																															
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																															
C	2011	N200	Chassis	Electronic Brake Control Module																																																															
C	2011	N200	Body	Supplemental Inflatable Restraint																																																															
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																															
C	2011	N300	Chassis	Electronic Brake Control Module																																																															
C	2011	N300	Body	Supplemental Inflatable Restraint																																																															
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																															
C	2012	N200	Chassis	Electronic Brake Control Module																																																															
C	2012	N200	Body	Supplemental Inflatable Restraint																																																															
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																																															
C	2012	N300	Chassis	Electronic Brake Control Module																																																															
C	2012	N300	Body	Supplemental Inflatable Restraint																																																															
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module																																																															
C	2013	N300	Chassis	Electronic Brake Control Module																																																															
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module																																																															
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																																															
C	2014	N300	Chassis	Electronic Brake Control Module																																																															
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module																																																															
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																																															
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																																															
C	2015	Max	Chassis	Electronic Brake Control Module																																																															
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module																																																															
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																																															
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																																															
C	2015	Move	Chassis	Electronic Brake Control Module																																																															
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module																																																															
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																																															
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																																															
C	2015	N300	Chassis	Electronic Brake Control Module																																																															
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module																																																													
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																																													
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																																													
C	2016	Max	Chassis	Electronic Brake Control Module																																																													
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module																																																													
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																																													
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																																													
C	2016	Move	Chassis	Electronic Brake Control Module																																																													
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module																																																													
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																																													
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																																													
C	2016	N300	Chassis	Electronic Brake Control Module																																																													
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																																													
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																																													
M	2015	City Express	Chassis	Electronic Brake Control Module																																																													
M	2015	City Express	Chassis	Power Steering Control Module																																																													
M	2015	City Express	Body	Body Control Module																						V																																						
M	2015	City Express	Body	Underhood Fuse Block																																																												
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2015	City Express	Body	Instrument Cluster																																																												
M	2015	City Express	Body	Tire Pressure Indicator Module																																																												
M	2015	City Express	Body	Radio																																																												
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																																												
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																																												
M	2016	City Express	Chassis	Electronic Brake Control Module																																																												
M	2016	City Express	Chassis	Power Steering Control Module																																																												
M	2016	City Express	Body	Body Control Module																						V																																						
M	2016	City Express	Body	Underhood Fuse Block																																																												
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
M	2016	City Express	Body	Instrument Cluster																																																												
M	2016	City Express	Body	Tire Pressure Indicator Module																																																												
M	2016	City Express	Body	Radio																																																												
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																																												
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																																												
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																																												
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																												
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																												
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																												
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																																												
P	2011	Orlando	Chassis	Electronic Brake Control Module																																																												
P	2011	Orlando	Chassis	Parking Brake Control Module																																																												
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																												
P	2011	Orlando	Chassis	Power Steering Control Module																																																												
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
P	2011	Orlando	Body	Body Control Module		

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																												
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																													
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																													
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																																													
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																													
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																																													
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																																													
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																																													
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																																													
P	2013	Orlando	Chassis	Electronic Brake Control Module																																																													
P	2013	Orlando	Chassis	Parking Brake Control Module																																																													
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																													
P	2013	Orlando	Chassis	Power Steering Control Module																																																													
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																													
P	2013	Orlando	Body	Body Control Module																																																													
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
P	2013	Orlando	Body	Instrument Cluster																																																													
P	2013	Orlando	Body	Radio																																																													
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																																													
P	2013	Orlando	Body	Multimedia Player Interface Module																																																													
P	2013	Orlando	Body	Mobile Telephone Control Module																																																													
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																													
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																													
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																																													
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																													
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																																													
P	2013	Orlando	Body	Front Seat Heating Control Module																																																													
P	2013	Orlando	Body	Keyless Entry Control Module																																																													
P	2013	Orlando	Body	Parking Assist Control Module																																																													
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																																													
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																																													
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																																													
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																																													
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																																													
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																													
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																													
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																													
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																													
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																													
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																													
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																													
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																													
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																													
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																													
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																													
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																																													
P	2014	Orlando	Chassis	Electronic Brake Control Module																																																													
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
P	2014	Orlando	Chassis	Power Steering Control Module																																																														
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																														
P	2014	Orlando	Body	Body Control Module																																																														
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
P	2014	Orlando	Body	Instrument Cluster																																																														
P	2014	Orlando	Body	Radio																																																														
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																																														
P	2014	Orlando	Body	Multimedia Player Interface Module																																																														
P	2014	Orlando	Body	Mobile Telephone Control Module																																																														
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																																														
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																																														
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																																														
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																														
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																																														
P	2014	Orlando	Body	Front Seat Heating Control Module																																																														
P	2014	Orlando	Body	Rear Seat Heating Control Module																																																														
P	2014	Orlando	Body	Keyless Entry Control Module																																																														
P	2014	Orlando	Body	Parking Assist Control Module																																																														
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																														
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																														
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																														
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																														
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																														
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																														
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																																														
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																																														
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																														
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																														
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																														
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																														
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																														
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																														
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																																														
P	2015	Orlando	Chassis	Electronic Brake Control Module																																																														
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																														
P	2015	Orlando	Chassis	Power Steering Control Module																																																														
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																														
P	2015	Orlando	Body	Body Control Module																																																														
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
P	2015	Orlando	Body	Instrument Cluster																																																														
P	2015	Orlando	Body	Radio																																																														
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																																														
P	2015	Orlando	Body	Mobile Telephone Control Module																																																														
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																																														
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																																														
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																														
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																																														
P	2015	Orlando	Body	Front Seat Heating Control Module																																																														
P	2015	Orlando	Body	Rear Seat Heating Control Module																																																														
P	2015	Orlando	Body	Keyless Entry Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
P	2015	Orlando	Body	Parking Assist Control Module																																																															
P	2015	Orlando	Body	Frontview Camera Module																																																															
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																																															
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																																															
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																																															
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																																															
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																																															
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																																															
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																																															
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																																															
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																																															
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																																															
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																																															
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																																															
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																																															
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																																															
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																																															
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																																															
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																																															
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																																															
P	2016	Orlando	Chassis	Electronic Brake Control Module																																																															
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																																															
P	2016	Orlando	Chassis	Power Steering Control Module																																																															
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																																															
P	2016	Orlando	Body	Body Control Module																																																															
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
P	2016	Orlando	Body	Instrument Cluster																																																															
P	2016	Orlando	Body	Radio																																																															
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																																															
P	2016	Orlando	Body	Multimedia Player Interface Module																																																															
P	2016	Orlando	Body	Mobile Telephone Control Module																																																															
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																																															
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																																															
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																																															
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																																															
P	2016	Orlando	Body	Front Seat Heating Control Module																																																															
P	2016	Orlando	Body	Rear Seat Heating Control Module																																																															
P	2016	Orlando	Body	Keyless Entry Control Module																																																															
P	2016	Orlando	Body	Parking Assist Control Module																																																															
P	2016	Orlando	Body	Frontview Camera Module																																																															
U	2004	ALL	Powertrain	Engine Control Module																																																															
U	2004	ALL	Powertrain	Transmission Control Module																																																															
U	2004	ALL	Body	Digital Radio Receiver																																																															
U	2004	ALL	Body	Driver Information Center																																																															
U	2004	ALL	Body	Instrument Panel Cluster																																																															
U	2004	ALL	Body	Radio																																																															
U	2004	ALL	Body	Supplemental Inflatable Restraint																																																															
U	2004	ALL	Body	Vehicle Theft Deterrent																																																															
U	2005	ALL	Powertrain	Engine Control Module																																																															
U	2005	ALL	Powertrain	Transmission Control Module																																																															
U	2005	ALL	Chassis	Electronic Brake Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
U	2005	ALL	Body	Body Control Module																																																																
U	2005	ALL	Body	Disc Player and Video																																																																
U	2005	ALL	Body	Digital Radio Receiver																																																																
U	2005	ALL	Body	HVAC Control Module																																																																
U	2005	ALL	Body	Instrument Panel Cluster																																																																
U	2005	ALL	Body	Left Power Sliding Door Module																																																																
U	2005	ALL	Body	Mobile Digital Media																																																																
U	2005	ALL	Body	Navigation Radio																																																																
U	2005	ALL	Body	Navigation Radio																																																																
U	2005	ALL	Body	Radio																																																																
U	2005	ALL	Body	Right Power Sliding Door Module																																																																
U	2005	ALL	Body	Supplemental Inflatable Restraint																																																																
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																																
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																																
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																																
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																																
U	2006	ALL	Chassis	Electronic Brake Control Module																																																																
U	2006	ALL	Body	Body Control Module																																																																
U	2006	ALL	Body	Disc Player and Video																																																																
U	2006	ALL	Body	Digital Radio Receiver																																																																
U	2006	ALL	Body	HVAC Control Module																																																																
U	2006	ALL	Body	Instrument Panel Cluster																																																																
U	2006	ALL	Body	Left Power Sliding Door Module																																																																
U	2006	ALL	Body	Mobile Digital Media																																																																
U	2006	ALL	Body	Navigation Radio																																																																
U	2006	ALL	Body	Navigation Radio																																																																
U	2006	ALL	Body	Radio																																																																
U	2006	ALL	Body	Right Power Sliding Door Module																																																																
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																																
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																																
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																																
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																																
U	2007	ALL	Chassis	Electronic Brake Control Module																																																																
U	2007	ALL	Body	Body Control Module																																																																
U	2007	ALL	Body	Digital Radio Receiver																																																																
U	2007	ALL	Body	Disc Player and Video Display																																																																
U	2007	ALL	Body	HVAC Control Module																																																																
U	2007	ALL	Body	Left Power Sliding Door Module																																																																
U	2007	ALL	Body	Mobile Digital Media																																																																
U	2007	ALL	Body	Radio																																																																
U	2007	ALL	Body	Navigation Radio																																																																
U	2007	ALL	Body	Right Power Sliding Door Module																																																																
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																																
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																																
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																																
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																																
U	2008	ALL	Chassis	Electronic Brake Control Module																																																																
U	2008	ALL	Body	Body Control Module																																																																
U	2008	ALL	Body	Digital Radio Receiver																																																																
U	2008	ALL	Body	Disc Player and Video Display																																																																
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																											
U	2008	ALL	Body	Left Power Sliding Door Module																																																												
U	2008	ALL	Body	Radio																																																											
U	2008	ALL	Body	Navigation Radio																																																											
U	2008	ALL	Body	Remote Control Door Lock Receiver																																																												
U	2008	ALL	Body	Right Power Sliding Door Module																																																												
U	2009	ALL	Powertrain	Engine Control Module																																																												
U	2009	ALL	Powertrain	Transmission Control Module																																																												
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																												
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																												
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																												
U	2009	ALL	Body	Body Control Module																																																												
U	2009	ALL	Body	Digital Radio Receiver																																																												
U	2009	ALL	Body	Disc Player and Video Display																																																												
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																																												
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																												
U	2009	ALL	Body	Instrument Panel Cluster																																																												
U	2009	ALL	Body	Left Power Sliding Door Module																																																												
U	2009	ALL	Body	Radio																																																												
U	2009	ALL	Body	Remote Control Door Lock Receiver																																																												
U	2009	ALL	Body	Right Power Sliding Door Module																																																												
V	2004	ALL	Powertrain	Engine Data Display																																																												
V	2004	ALL	Powertrain	Transmission Data Display																																																												
V	2004	ALL	Body	Digital Radio Receiver																																																												
V	2004	ALL	Body	Driver Information Center																																																												
V	2004	ALL	Body	Instrument Panel Cluster																																																												
V	2004	ALL	Body	Radio																																																												
V	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2004	ALL	Body	Vehicle Theft Deterrent																																																												
V	2005	Venture	Powertrain	Engine Control Module																																																												
V	2005	Venture	Powertrain	Transmission Control Module																																																												
V	2005	Venture	Body	Digital Radio Receiver																																																												
V	2005	Venture	Body	Driver Information Center																																																												
V	2005	Venture	Body	Instrument Panel Cluster																																																												
V	2005	Venture	Body	Radio																																																												
V	2005	Venture	Body	Supplemental Inflatable Restraint																																																												
V	2005	Venture	Body	Vehicle Theft Deterrent																																																												
V	2005	Uplander	Powertrain	Engine Control Module																																																												
V	2005	Uplander	Powertrain	Transmission Control Module																																																												
V	2005	Uplander	Chassis	Electronic Brake Control Module																																																												
V	2005	Uplander	Body	Body Control Module																																																												
V	2005	Uplander	Body	Disc Player and Video																																																												
V	2005	Uplander	Body	Digital Radio Receiver																																																												
V	2005	Uplander	Body	HVAC Control Module																																																												
V	2005	Uplander	Body	Instrument Panel Cluster																																																												
V	2005	Uplander	Body	Left Power Sliding Door Module																																																												
V	2005	Uplander	Body	Mobile Digital Media																																																												
V	2005	Uplander	Body	Navigation Radio																																																												
V	2005	Uplander	Body	Navigation Radio																																																												
V	2005	Uplander	Body	Radio																																																												
V	2005	Uplander	Body	Right Power Sliding Door Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
V	2005	Uplander	Body	Supplemental Inflatable Restraint																																																												
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																													
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																													
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																																													
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																																													
V	2006	ALL	Chassis	Electronic Brake Control Module																																																													
V	2006	ALL	Body	Body Control Module																																																													
V	2006	ALL	Body	Disc Player and Video																																																													
V	2006	ALL	Body	Digital Radio Receiver																																																													
V	2006	ALL	Body	HVAC Control Module																																																													
V	2006	ALL	Body	Instrument Panel Cluster																																																													
V	2006	ALL	Body	Left Power Sliding Door Module																																																													
V	2006	ALL	Body	Mobile Digital Media																																																													
V	2006	ALL	Body	Navigation Radio																																																													
V	2006	ALL	Body	Navigation Radio																																																													
V	2006	ALL	Body	Radio																																																													
V	2006	ALL	Body	Right Power Sliding Door Module																																																													
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																													
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																													
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																													
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																													
V	2007	ALL	Chassis	Electronic Brake Control Module																																																													
V	2007	ALL	Body	Body Control Module																																																													
V	2007	ALL	Body	Digital Radio Receiver																																																													
V	2007	ALL	Body	Disc Player and Video Display																																																													
V	2007	ALL	Body	HVAC Control Module																																																													
V	2007	ALL	Body	Left Power Sliding Door Module																																																													
V	2007	ALL	Body	Mobile Digital Media																																																													
V	2007	ALL	Body	Radio																																																													
V	2007	ALL	Body	Navigation Radio																																																													
V	2007	ALL	Body	Right Power Sliding Door Module																																																													
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																																													
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																																													
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																																													
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																																													
V	2008	ALL	Chassis	Electronic Brake Control Module																																																													
V	2008	ALL	Body	Body Control Module																																																													
V	2008	ALL	Body	Digital Radio Receiver																																																													
V	2008	ALL	Body	Disc Player and Video Display																																																													
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																																													
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																																													
V	2008	ALL	Body	Left Power Sliding Door Module																																																													
V	2008	ALL	Body	Radio																																																													
V	2008	ALL	Body	Navigation Radio																																																													
V	2008	ALL	Body	Remote Control Door Lock Receiver																																																													
V	2008	ALL	Body	Right Power Sliding Door Module																																																													
V	2009	ALL	Powertrain	Engine Control Module																																																													
V	2009	ALL	Powertrain	Transmission Control Module																																																													
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																																													
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																																													
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
V	2009	ALL	Body	Body Control Module																																																												
V	2009	ALL	Body	Digital Radio Receiver																																																													
V	2009	ALL	Body	Disc Player and Video Display																																																													
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																																													
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																																													
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																																													
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																																													
V	2009	ALL	Body	Left Power Sliding Door Module																																																													
V	2009	ALL	Body	Radio																																																													
V	2009	ALL	Body	Remote Control Door Lock Receiver																																																													
V	2009	ALL	Body	Right Power Sliding Door Module																																																													
X	2004	ALL	Powertrain	Engine Control Module																																																														
X	2004	ALL	Powertrain	Transmission Control Module																																																														
X	2004	ALL	Body	Digital Radio Receiver																																																														
X	2004	ALL	Body	Driver Information Center																																																														
X	2004	ALL	Body	Instrument Panel Cluster																																																														
X	2004	ALL	Body	Radio																																																														
X	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
X	2004	ALL	Body	Vehicle Theft Deterrent																																																														
X	2005	ALL	Powertrain	Engine Control Module																																																														
X	2005	ALL	Powertrain	Transmission Control Module																																																														
X	2005	ALL	Chassis	Electronic Brake Control Module																																																														
X	2005	ALL	Body	Body Control Module																																																														
X	2005	ALL	Body	Disc Player and Video																																																														
X	2005	ALL	Body	Digital Radio Receiver																																																														
X	2005	ALL	Body	HVAC Control Module																																																														
X	2005	ALL	Body	Instrument Panel Cluster																																																														
X	2005	ALL	Body	Left Power Sliding Door Module																																																														
X	2005	ALL	Body	Mobile Digital Media																																																														
X	2005	ALL	Body	Navigation Radio																																																														
X	2005	ALL	Body	Navigation Radio																																																														
X	2005	ALL	Body	Radio																																																														
X	2005	ALL	Body	Right Power Sliding Door Module																																																														
X	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																																																														
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																																														
X	2006	ALL	Chassis	Electronic Brake Control Module																																																														
X	2006	ALL	Body	Body Control Module																																																														
X	2006	ALL	Body	Disc Player and Video																																																														
X	2006	ALL	Body	Digital Radio Receiver																																																														
X	2006	ALL	Body	HVAC Control Module																																																														
X	2006	ALL	Body	Instrument Panel Cluster																																																														
X	2006	ALL	Body	Left Power Sliding Door Module																																																														
X	2006	ALL	Body	Mobile Digital Media																																																														
X	2006	ALL	Body	Navigation Radio																																																														
X	2006	ALL	Body	Navigation Radio																																																														
X	2006	ALL	Body	Radio																																																														
X	2006	ALL	Body	Right Power Sliding Door Module																																																														

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
A	2006	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																								
A	2006	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																								
A	2006	ALL	Powertrain	Transmission Control Module																																								
A	2006	ALL	Chassis	Electronic Brake Control Module																																								
A	2006	ALL	Chassis	Power Steering Control Module																																								
A	2006	ALL	Body	Body Control Module																																								
A	2006	ALL	Body	Digital Radio Receiver																																								
A	2006	ALL	Body	Instrument Panel Cluster																																								
A	2006	ALL	Body	Radio																																								
A	2006	ALL	Body	Supplemental Inflatable Restraint																																								
A	2006	ALL	Body	Theft Deterrent Module																																								
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Engine Control Module																																								
A	2007	ALL	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																								
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																								
A	2007	ALL	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																								
A	2007	ALL	Chassis	Electronic Brake Control Module																																								
A	2007	ALL	Chassis	Power Steering Control Module																																								
A	2007	ALL	Body	Body Control Module																																								
A	2007	ALL	Body	Digital Radio Receiver																																								
A	2007	ALL	Body	Instrument Panel Cluster																																								
A	2007	ALL	Body	Radio																																								
A	2007	ALL	Body	Supplemental Inflatable Restraint																																								
A	2007	ALL	Body	Theft Deterrent Module																																								
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																								
A	2008	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																								
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Engine Control Module																																								
A	2008	HHR	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																								
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																								
A	2008	HHR	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																								
A	2008	HHR	Chassis	Electronic Brake Control Module With VSES																																								
A	2008	HHR	Chassis	Electronic Brake Control Module Without VSES																																								
A	2008	HHR	Chassis	Power Steering Control Module																																								
A	2008	HHR	Chassis	Power Steering Control Module																																								
A	2008	HHR	Body	Body Control Module																																								
A	2008	HHR	Body	Digital Radio Receiver																																								
A	2008	HHR	Body	Instrument Panel Cluster																																								
A	2008	HHR	Body	Radio																																								
A	2008	HHR	Body	Supplemental Inflatable Restraint																																								
A	2008	HHR	Body	Theft Deterrent Module																																								
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																								
A	2008	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																								
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Engine Control Module																																								
A	2008	HHR Panel	Powertrain	(D)2.2L L4 L61 Transmission Control Module																																								
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																								
A	2008	HHR Panel	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																								
A	2008	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																								
A	2008	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																								
A	2008	HHR Panel	Chassis	Power Steering Control Module																																								
A	2008	HHR Panel	Chassis	Power Steering Control Module																																								
A	2008	HHR Panel	Body	Body Control Module																																								
A	2008	HHR Panel	Body	Digital Radio Receiver																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
A	2008	HHR Panel	Body	Instrument Panel Cluster																																								
A	2008	HHR Panel	Body	Radio																																								
A	2008	HHR Panel	Body	Supplemental Inflatable Restraint																																								
A	2008	HHR Panel	Body	Theft Deterrent Module																																								
A	2008	Tracker	Powertrain	(J)2.0L L4 L34 Engine Control Module																																								
A	2008	Tracker	Chassis	Electronic Brake Control Module With VSES																																								
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Engine Control Module																																								
A	2009	HHR	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																								
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																								
A	2009	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																								
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																								
A	2009	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																								
A	2009	HHR	Chassis	Electronic Brake Control Module With VSES																																								
A	2009	HHR	Chassis	Electronic Brake Control Module Without VSES																																								
A	2009	HHR	Chassis	Power Steering Control Module																																								
A	2009	HHR	Chassis	Power Steering Control Module																																								
A	2009	HHR	Body	Body Control Module																																								
A	2009	HHR	Body	Digital Radio Receiver																																								
A	2009	HHR	Body	Instrument Panel Cluster																																								
A	2009	HHR	Body	Radio																																								
A	2009	HHR	Body	Supplemental Inflatable Restraint																																								
A	2009	HHR	Body	Theft Deterrent Module																																								
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Engine Control Module																																								
A	2009	HHR Panel	Powertrain	(X)2.0L L4 LNF Transmission Control Module																																								
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																								
A	2009	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																								
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																								
A	2009	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																								
A	2009	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																								
A	2009	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																								
A	2009	HHR Panel	Chassis	Power Steering Control Module																																								
A	2009	HHR Panel	Chassis	Power Steering Control Module																																								
A	2009	HHR Panel	Body	Body Control Module																																								
A	2009	HHR Panel	Body	Digital Radio Receiver																																								
A	2009	HHR Panel	Body	Instrument Panel Cluster																																								
A	2009	HHR Panel	Body	Radio																																								
A	2009	HHR Panel	Body	Supplemental Inflatable Restraint																																								
A	2009	HHR Panel	Body	Theft Deterrent Module																																								
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Engine Control Module																																								
A	2010	HHR	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																								
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																								
A	2010	HHR	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																								
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																								
A	2010	HHR	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																								
A	2010	HHR	Chassis	Electronic Brake Control Module With VSES																																								
A	2010	HHR	Chassis	Electronic Brake Control Module Without VSES																																								
A	2010	HHR	Chassis	Power Steering Control Module																																								
A	2010	HHR	Chassis	Power Steering Control Module																																								
A	2010	HHR	Body	Body Control Module																																								
A	2010	HHR	Body	Digital Radio Receiver																																								
A	2010	HHR	Body	Instrument Panel Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Thefflock LED
A	2010	HHR	Body	Radio																																								
A	2010	HHR	Body	Supplemental Inflatable Restraint																																								
A	2010	HHR	Body	Theft Deterrent Module																																								
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Engine Control Module																																								
A	2010	HHR Panel	Powertrain	(M)2.0L L4 LNF Transmission Control Module																																								
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Engine Control Module																																								
A	2010	HHR Panel	Powertrain	(B)2.2L L4 LE8 Transmission Control Module																																								
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																								
A	2010	HHR Panel	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																								
A	2010	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																								
A	2010	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																								
A	2010	HHR Panel	Chassis	Power Steering Control Module																																								
A	2010	HHR Panel	Chassis	Power Steering Control Module																																								
A	2010	HHR Panel	Body	Body Control Module																																								
A	2010	HHR Panel	Body	Digital Radio Receiver																																								
A	2010	HHR Panel	Body	Instrument Panel Cluster																																								
A	2010	HHR Panel	Body	Radio																																								
A	2010	HHR Panel	Body	Supplemental Inflatable Restraint																																								
A	2010	HHR Panel	Body	Theft Deterrent Module																																								
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																								
A	2011	HHR	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																								
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																								
A	2011	HHR	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																								
A	2011	HHR	Chassis	Electronic Brake Control Module With VSES																																								
A	2011	HHR	Chassis	Electronic Brake Control Module Without VSES																																								
A	2011	HHR	Chassis	Power Steering Control Module																																								
A	2011	HHR	Body	Body Control Module																																								
A	2011	HHR	Body	Digital Radio Receiver																																								
A	2011	HHR	Body	Instrument Panel Cluster																																								
A	2011	HHR	Body	Radio																																								
A	2011	HHR	Body	Supplemental Inflatable Restraint																																								
A	2011	HHR	Body	Theft Deterrent Module																																								
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Engine Control Module																																								
A	2011	HHR Panel	Powertrain	(W)2.2L L4 LE8 Transmission Control Module																																								
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Engine Control Module																																								
A	2011	HHR Panel	Powertrain	(U)2.4L L4 LE9 Transmission Control Module																																								
A	2011	HHR Panel	Chassis	Electronic Brake Control Module With VSES																																								
A	2011	HHR Panel	Chassis	Electronic Brake Control Module Without VSES																																								
A	2011	HHR Panel	Chassis	Power Steering Control Module																																								
A	2011	HHR Panel	Body	Body Control Module																																								
A	2011	HHR Panel	Body	Digital Radio Receiver																																								
A	2011	HHR Panel	Body	Instrument Panel Cluster																																								
A	2011	HHR Panel	Body	Radio																																								
A	2011	HHR Panel	Body	Supplemental Inflatable Restraint																																								
A	2011	HHR Panel	Body	Theft Deterrent Module																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																								
A	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																								
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																								
A	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																								
A	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																								
A	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																								
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																								
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																								
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																								
A	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																								
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																								
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																								
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																								
A	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																								
A	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																								
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																								
A	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																								
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																								
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																								
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																								
A	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																								
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																								
A	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																								
A	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
A	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																								
A	2013	Trax	Chassis	Electronic Brake Control Module																																								
A	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																								
A	2013	Trax	Chassis	Power Steering Control Module																																								
A	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																								
A	2013	Trax	Body	Body Control Module																																								
A	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
A	2013	Trax	Body	Passenger Presence Module																																								
A	2013	Trax	Body	Instrument Cluster																																								
A	2013	Trax	Body	Radio																																								
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																								
A	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																								
A	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																								
A	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																								
A	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																								
A	2013	Trax	Body	Front Seat Heating Control Module																																								
A	2013	Trax	Body	Parking Assist Control Module																																								
A	2013	Trax	Body	Frontview Camera Module																																								
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																								
A	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																								
A	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																								
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								
A	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								
A	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																								
A	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																								
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																								
A	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																								
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
A	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																								
A	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																								
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																								
A	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																								
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																								
A	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																								
A	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
A	2014	Trax	Powertrain	Fuel Injector Control Module																																								
A	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																								
A	2014	Trax	Chassis	Electronic Brake Control Module																																								
A	2014	Trax	Chassis	Power Steering Control Module																																								
A	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																								
A	2014	Trax	Body	Body Control Module																																								
A	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
A	2014	Trax	Body	Passenger Presence Module																																								
A	2014	Trax	Body	Instrument Cluster																																								
A	2014	Trax	Body	Radio																																								
A	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																								
A	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																								
A	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																								
A	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																								
A	2014	Trax	Body	Front Seat Heating Control Module																																								
A	2014	Trax	Body	Parking Assist Control Module																																								
A	2014	Trax	Body	Frontview Camera Module																																								
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
A	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
A	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																								
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								
A	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								
A	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																								
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																								
A	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																								
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																								
A	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																								
A	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																								
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																								
A	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																								
A	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																								
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																								
A	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																								
A	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
A	2015	Trax	Powertrain	Fuel Injector Control Module																																								
A	2015	Trax	Powertrain	Chassis Control Module																																								
A	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																								
A	2015	Trax	Chassis	Electronic Brake Control Module																																								
A	2015	Trax	Chassis	Power Steering Control Module																																								
A	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																								
A	2015	Trax	Body	Body Control Module																																								
A	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
A	2015	Trax	Body	Passenger Presence Module																																								
A	2015	Trax	Body	Instrument Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
A	2015	Trax	Body	Radio																																								
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																								
A	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																								
A	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																								
A	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																								
A	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																								
A	2015	Trax	Body	Seat Memory Control Module																																								
A	2015	Trax	Body	Front Seat Heating Control Module																																								
A	2015	Trax	Body	Right Side Object Detection Control Module																																								
A	2015	Trax	Body	Left Side Object Detection Control Module																																								
A	2015	Trax	Body	Parking Assist Control Module																																								
A	2015	Trax	Body	Frontview Camera Module																																								
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																								
A	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																								
A	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																								
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																								
A	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																								
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
A	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
A	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																								
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								
A	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								
A	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																								
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																								
A	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																								
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																								
A	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																								
A	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																								
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																								
A	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																								
A	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
A	2016	Trax	Powertrain	Fuel Injector Control Module																																								
A	2016	Trax	Powertrain	Chassis Control Module																																								
A	2016	Trax	Chassis	Electronic Brake Control Module																																								
A	2016	Trax	Chassis	Power Steering Control Module																																								
A	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																								
A	2016	Trax	Body	Body Control Module																																								
A	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
A	2016	Trax	Body	Passenger Presence Module																																								
A	2016	Trax	Body	Instrument Cluster																																								
A	2016	Trax	Body	Trailer Interface Control Module																																								
A	2016	Trax	Body	Radio																																								
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																								
A	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																								
A	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																								
A	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																								
A	2016	Trax	Body	Seat Memory Control Module																																								
A	2016	Trax	Body	Front Seat Heating Control Module																																								
A	2016	Trax	Body	Right Side Object Detection Control Module																																								
A	2016	Trax	Body	Left Side Object Detection Control Module																																								
A	2016	Trax	Body	Parking Assist Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
A	2016	Trax	Body	Frontview Camera Module																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																								
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																								
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																								
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																								
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																								
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
C	2004	ALL	Chassis	ABS Over 8600 GVW																																								
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																								
C	2004	ALL	Chassis	ESC																																								
C	2004	ALL	Chassis	Rear Wheel Steering																																								
C	2004	ALL	Chassis	Tire Pressure Monitor																																								
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																								
C	2004	ALL	Chassis	VSES																																								
C	2004	ALL	Body	Amplifier (Bose)																																								
C	2004	ALL	Body	Body Control Module																																								
C	2004	ALL	Body	CD Changer																																								
C	2004	ALL	Body	Chime																																								
C	2004	ALL	Body	Driver Door Module																																								
C	2004	ALL	Body	Driver Seat Module																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto																																								
C	2004	ALL	Body	Heating and Air Conditioning Manual																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																								
C	2004	ALL	Body	Instrument Panel Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2004	ALL	Body	OnStar																																								
C	2004	ALL	Body	Passenger Door Module																																								
C	2004	ALL	Body	Passenger Presence System																																								
C	2004	ALL	Body	Radio Base																																								
C	2004	ALL	Body	Radio Uplevel																																								
C	2004	ALL	Body	Radio Navigation																																								
C	2004	ALL	Body	Rear Aux. Climate Module																																								
C	2004	ALL	Body	Rear HVAC																																								
C	2004	ALL	Body	Rear Seat Audio																																								
C	2004	ALL	Body	Rear Seat Entertainment																																								
C	2004	ALL	Body	Supplemental Inflatable Restraint																																								
C	2004	ALL	Body	Vehicle Theft Deterrent																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																								
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																								
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																								
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																								
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																								
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
C	2005	ALL	Chassis	ABS Over 8600 GVW																																								
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																								
C	2005	ALL	Chassis	ESC																																								
C	2005	ALL	Chassis	Rear Wheel Steering																																								
C	2005	ALL	Chassis	Tire Pressure Monitor																																								
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2005	ALL	Chassis	VSES																																								
C	2005	ALL	Body	Amplifier (Bose)																																								
C	2005	ALL	Body	Body Control Module																																								
C	2005	ALL	Body	CD Changer																																								
C	2005	ALL	Body	Chime																																								
C	2005	ALL	Body	Disc Player and Video Display																																								
C	2005	ALL	Body	Driver Door Module																																								
C	2005	ALL	Body	Driver Seat Module																																								
C	2005	ALL	Body	Generator Battery Control Module																																								
C	2005	ALL	Body	Heating and Air Conditioning Auto																																								
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																								
C	2005	ALL	Body	Heating and Air Conditioning Manual																																								
C	2005	ALL	Body	Instrument Panel Cluster																																								
C	2005	ALL	Body	Passenger Door Module																																								
C	2005	ALL	Body	Passenger Presence System																																								
C	2005	ALL	Body	Base Radio																																								
C	2005	ALL	Body	Uplevel Radio																																								
C	2005	ALL	Body	Navigation Radio																																								
C	2005	ALL	Body	Rear Aux. Climate Module																																								
C	2005	ALL	Body	Rear HVAC																																								
C	2005	ALL	Body	Rear Seat Audio																																								
C	2005	ALL	Body	Supplemental Inflatable Restraint																																								
C	2005	ALL	Body	Vehicle Comm. Interface Module																																								
C	2005	ALL	Body	Vehicle Theft Deterrent																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																								
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																								
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																								
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																								
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																								
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																								
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																								
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																								
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																								
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
C	2006	ALL	Chassis	ABS Over 8600 GVW																																								
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																								
C	2006	ALL	Chassis	ESC																																								
C	2006	ALL	Chassis	Tire Pressure Monitor																																								
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																								
C	2006	ALL	Chassis	VSES																																								
C	2006	ALL	Body	Amplifier (Bose)																																								
C	2006	ALL	Body	Body Control Module																																								
C	2006	ALL	Body	CD Changer																																								
C	2006	ALL	Body	Chime																																								
C	2006	ALL	Body	Disc Player and Video Display																																								
C	2006	ALL	Body	Driver Door Module																																								
C	2006	ALL	Body	Driver Seat Module																																								
C	2006	ALL	Body	Generator Battery Control Module																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																								
C	2006	ALL	Body	Heating and Air Conditioning Manual																																								
C	2006	ALL	Body	Instrument Panel Cluster																																								
C	2006	ALL	Body	Passenger Door Module																																								
C	2006	ALL	Body	Passenger Presence System																																								
C	2006	ALL	Body	Base Radio																																								
C	2006	ALL	Body	Uplevel Radio																																								
C	2006	ALL	Body	Navigation Radio																																								
C	2006	ALL	Body	Rear Aux. Climate Module																																								
C	2006	ALL	Body	Rear HVAC																																								
C	2006	ALL	Body	Rear Seat Audio																																								
C	2006	ALL	Body	Supplemental Inflatable Restraint																																								
C	2006	ALL	Body	Vehicle Theft Deterrent																																								
C	2006	ALL	Body	Vehicle Comm. Interface Module																																								
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2007	Avalanche	Chassis	Electronic Suspension Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2007	Avalanche	Chassis	Trailer Brake Control Module																																								
C	2007	Avalanche	Body	Amplifier (Bose)																																								
C	2007	Avalanche	Body	Assist Step Controller																																								
C	2007	Avalanche	Body	Body Control Module																																								
C	2007	Avalanche	Body	Body Control Module (aux.)																																								
C	2007	Avalanche	Body	Digital Radio Receiver																																								
C	2007	Avalanche	Body	Driver Door Switch																																								
C	2007	Avalanche	Body	HVAC Control Module Auto																																								
C	2007	Avalanche	Body	HVAC Control Module Manual																																								
C	2007	Avalanche	Body	Instrument Panel Cluster																																								
C	2007	Avalanche	Body	Memory Seat Module																																								
C	2007	Avalanche	Body	Park Assist Module																																								
C	2007	Avalanche	Body	Passenger Door Switch																																								
C	2007	Avalanche	Body	Passenger Presence System																																								
C	2007	Avalanche	Body	Radio																																								
C	2007	Avalanche	Body	Rear Heated Seat Module																																								
C	2007	Avalanche	Body	Rear HVAC/RSA																																								
C	2007	Avalanche	Body	Rollover Sensor																																								
C	2007	Avalanche	Body	Supplemental Inflatable Restraint																																								
C	2007	Avalanche	Body	Theft Deterrent Module																																								
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2007	Suburban	Chassis	Electronic Suspension Control																																								
C	2007	Suburban	Chassis	Trailer Brake Control Module																																								
C	2007	Suburban	Body	Amplifier (Bose)																																								
C	2007	Suburban	Body	Assist Step Controller																																								
C	2007	Suburban	Body	Body Control Module																																								
C	2007	Suburban	Body	Body Control Module (aux.)																																								
C	2007	Suburban	Body	Digital Radio Receiver																																								
C	2007	Suburban	Body	Driver Door Switch																																								
C	2007	Suburban	Body	HVAC Control Module Auto																																								
C	2007	Suburban	Body	HVAC Control Module Manual																																								
C	2007	Suburban	Body	Instrument Panel Cluster																																								
C	2007	Suburban	Body	Lift Gate Module																																								
C	2007	Suburban	Body	Memory Seat Module																																								
C	2007	Suburban	Body	Park Assist Module																																								
C	2007	Suburban	Body	Passenger Door Switch																																								
C	2007	Suburban	Body	Passenger Presence System																																								
C	2007	Suburban	Body	Radio																																								
C	2007	Suburban	Body	Rear Heated Seat Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2007	Suburban	Body	Rear HVAC/RSA																																								
C	2007	Suburban	Body	Rollover Sensor																																								
C	2007	Suburban	Body	Supplemental Inflatable Restraint																																								
C	2007	Suburban	Body	Theft Deterrent Module																																								
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
C	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
C	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
C	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
C	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
C	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2007	Silverado	Chassis	Electronic Suspension Control																																								
C	2007	Silverado	Chassis	Trailer Brake Control Module																																								
C	2007	Silverado	Body	Amplifier (Bose)																																								
C	2007	Silverado	Body	Body Control Module																																								
C	2007	Silverado	Body	Body Control Module (aux.)																																								
C	2007	Silverado	Body	Digital Radio Receiver																																								
C	2007	Silverado	Body	Driver Door Switch																																								
C	2007	Silverado	Body	HVAC Control Module Auto																																								
C	2007	Silverado	Body	HVAC Control Module Manual																																								
C	2007	Silverado	Body	Instrument Panel Cluster																																								
C	2007	Silverado	Body	Memory Seat Module																																								
C	2007	Silverado	Body	Park Assist Module																																								
C	2007	Silverado	Body	Passenger Door Switch																																								
C	2007	Silverado	Body	Passenger Presence System																																								
C	2007	Silverado	Body	Radio																																								
C	2007	Silverado	Body	Rear Heated Seat Module																																								
C	2007	Silverado	Body	Rear HVAC/RSA																																								
C	2007	Silverado	Body	Rollover Sensor																																								
C	2007	Silverado	Body	Supplemental Inflatable Restraint																																								
C	2007	Silverado	Body	Theft Deterrent Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
C	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2007	Tahoe	Chassis	Electronic Suspension Control																																								
C	2007	Tahoe	Chassis	Trailer Brake Control Module																																								
C	2007	Tahoe	Body	Amplifier (Bose)																																								
C	2007	Tahoe	Body	Assist Step Controller																																								
C	2007	Tahoe	Body	Body Control Module																																								
C	2007	Tahoe	Body	Body Control Module (aux.)																																								
C	2007	Tahoe	Body	Digital Radio Receiver																																								
C	2007	Tahoe	Body	Driver Door Switch																																								
C	2007	Tahoe	Body	HVAC Control Module Auto																																								
C	2007	Tahoe	Body	HVAC Control Module Manual																																								
C	2007	Tahoe	Body	Instrument Panel Cluster																																								
C	2007	Tahoe	Body	Lift Gate Module																																								
C	2007	Tahoe	Body	Memory Seat Module																																								
C	2007	Tahoe	Body	Park Assist Module																																								
C	2007	Tahoe	Body	Passenger Door Switch																																								
C	2007	Tahoe	Body	Passenger Presence System																																								
C	2007	Tahoe	Body	Radio																																								
C	2007	Tahoe	Body	Rear Heated Seat Module																																								
C	2007	Tahoe	Body	Rear HVAC/RSA																																								
C	2007	Tahoe	Body	Rollover Sensor																																								
C	2007	Tahoe	Body	Supplemental Inflatable Restraint																																								
C	2007	Tahoe	Body	Theft Deterrent Module																																								
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
C	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2008	Avalanche	Chassis	Electronic Brake Control Module																																								
C	2008	Avalanche	Chassis	Electronic Suspension Control																																								
C	2008	Avalanche	Chassis	Trailer Brake Control Module																																								
C	2008	Avalanche	Body	Amplifier (Bose)																																								
C	2008	Avalanche	Body	Assist Step Controller																																								
C	2008	Avalanche	Body	Body Control Module																																								
C	2008	Avalanche	Body	Body Control Module (aux.)																																								
C	2008	Avalanche	Body	Digital Radio Receiver																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2008	Avalanche	Body	Driver Door Switch																																								
C	2008	Avalanche	Body	HVAC Control Module Auto																																								
C	2008	Avalanche	Body	HVAC Control Module Manual																																								
C	2008	Avalanche	Body	Instrument Panel Cluster																																								
C	2008	Avalanche	Body	Memory Seat Module																																								
C	2008	Avalanche	Body	Park Assist Module																																								
C	2008	Avalanche	Body	Passenger Door Switch																																								
C	2008	Avalanche	Body	Passenger Presence System																																								
C	2008	Avalanche	Body	Radio																																								
C	2008	Avalanche	Body	Rear Heated Seat Module																																								
C	2008	Avalanche	Body	Rear HVAC/RSA																																								
C	2008	Avalanche	Body	Rollover Sensor																																								
C	2008	Avalanche	Body	Supplemental Inflatable Restraint																																								
C	2008	Avalanche	Body	Theft Deterrent Module																																								
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
C	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2008	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2008	Suburban	Chassis	Electronic Suspension Control																																								
C	2008	Suburban	Chassis	Trailer Brake Control Module																																								
C	2008	Suburban	Body	Amplifier (Bose)																																								
C	2008	Suburban	Body	Assist Step Controller																																								
C	2008	Suburban	Body	Body Control Module																																								
C	2008	Suburban	Body	Body Control Module (aux.)																																								
C	2008	Suburban	Body	Digital Radio Receiver																																								
C	2008	Suburban	Body	Driver Door Switch																																								
C	2008	Suburban	Body	HVAC Control Module Auto																																								
C	2008	Suburban	Body	HVAC Control Module Manual																																								
C	2008	Suburban	Body	Instrument Panel Cluster																																								
C	2008	Suburban	Body	Lift Gate Module																																								
C	2008	Suburban	Body	Memory Seat Module																																								
C	2008	Suburban	Body	Park Assist Module																																								
C	2008	Suburban	Body	Passenger Door Switch																																								
C	2008	Suburban	Body	Passenger Presence System																																								
C	2008	Suburban	Body	Radio																																								
C	2008	Suburban	Body	Rear Heated Seat Module																																								
C	2008	Suburban	Body	Rear HVAC/RSA																																								
C	2008	Suburban	Body	Rollover Sensor																																								
C	2008	Suburban	Body	Supplemental Inflatable Restraint																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2008	Suburban	Body	Theft Deterrent Module																																								
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
C	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
C	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
C	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
C	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
C	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2008	Silverado	Chassis	Electronic Suspension Control																																								
C	2008	Silverado	Chassis	Trailer Brake Control Module																																								
C	2008	Silverado	Body	Amplifier (Bose)																																								
C	2008	Silverado	Body	Body Control Module																																								
C	2008	Silverado	Body	Body Control Module (aux.)																																								
C	2008	Silverado	Body	Digital Radio Receiver																																								
C	2008	Silverado	Body	Driver Door Switch																																								
C	2008	Silverado	Body	HVAC Control Module Auto																																								
C	2008	Silverado	Body	HVAC Control Module Manual																																								
C	2008	Silverado	Body	Instrument Panel Cluster																																								
C	2008	Silverado	Body	Memory Seat Module																																								
C	2008	Silverado	Body	Park Assist Module																																								
C	2008	Silverado	Body	Passenger Door Switch																																								
C	2008	Silverado	Body	Passenger Presence System																																								
C	2008	Silverado	Body	Radio																																								
C	2008	Silverado	Body	Rear Heated Seat Module																																								
C	2008	Silverado	Body	Rear HVAC/RSA																																								
C	2008	Silverado	Body	Rollover Sensor																																								
C	2008	Silverado	Body	Supplemental Inflatable Restraint																																								
C	2008	Silverado	Body	Theft Deterrent Module																																								
C	2008	Tracker	Powertrain	(J)2.0L L4 L34 Powertrain Control Module																																								
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
C	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																								
C	2008	Tahoe	Chassis	Electronic Brake Control Module																																								
C	2008	Tahoe	Chassis	Electronic Suspension Control																																								
C	2008	Tahoe	Chassis	Trailer Brake Control Module																																								
C	2008	Tahoe	Body	Amplifier (Bose)																																								
C	2008	Tahoe	Body	Assist Step Controller																																								
C	2008	Tahoe	Body	Body Control Module																																								
C	2008	Tahoe	Body	Body Control Module (aux.)																																								
C	2008	Tahoe	Body	Digital Radio Receiver																																								
C	2008	Tahoe	Body	Driver Door Switch																																								
C	2008	Tahoe	Body	HVAC Control Module Auto																																								
C	2008	Tahoe	Body	HVAC Control Module Manual																																								
C	2008	Tahoe	Body	Instrument Panel Cluster																																								
C	2008	Tahoe	Body	Memory Seat Module																																								
C	2008	Tahoe	Body	Park Assist Module																																								
C	2008	Tahoe	Body	Passenger Presence System																																								
C	2008	Tahoe	Body	Radio																																								
C	2008	Tahoe	Body	Rear Heated Seat Module																																								
C	2008	Tahoe	Body	Rear HVAC/RSA																																								
C	2008	Tahoe	Body	Rollover Sensor																																								
C	2008	Tahoe	Body	Supplemental Inflatable Restraint																																								
C	2008	Tahoe	Body	Theft Deterrent Module																																								
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
C	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																								
C	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																								
C	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																								
C	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																								
C	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																								
C	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																								
C	2008	Tahoe Hybrid	Body	Body Control Module																																								
C	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																								
C	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																								
C	2008	Tahoe Hybrid	Body	Driver Door Switch																																								
C	2008	Tahoe Hybrid	Body	HVAC Control Module																																								
C	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																								
C	2008	Tahoe Hybrid	Body	Memory Seat Module																																								
C	2008	Tahoe Hybrid	Body	Park Assist Module																																								
C	2008	Tahoe Hybrid	Body	Passenger Presence System																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2008	Tahoe Hybrid	Body	Radio																																								
C	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																								
C	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																								
C	2008	Tahoe Hybrid	Body	Rollover Sensor																																								
C	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																								
C	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																								
C	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																								
C	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																								
C	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																								
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
C	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2009	Avalanche	Chassis	Electronic Brake Control Module																																								
C	2009	Avalanche	Chassis	Electronic Suspension Control																																								
C	2009	Avalanche	Chassis	Trailer Brake Control Module																																								
C	2009	Avalanche	Body	Amplifier (Bose)																																								
C	2009	Avalanche	Body	Assist Step Controller																																								
C	2009	Avalanche	Body	Body Control Module																																								
C	2009	Avalanche	Body	Body Control Module (aux.)																																								
C	2009	Avalanche	Body	Digital Radio Receiver																																								
C	2009	Avalanche	Body	Driver Door Switch																																								
C	2009	Avalanche	Body	HVAC Control Module Auto																																								
C	2009	Avalanche	Body	HVAC Control Module Manual																																								
C	2009	Avalanche	Body	Instrument Panel Cluster																																								
C	2009	Avalanche	Body	Memory Seat Module																																								
C	2009	Avalanche	Body	Park Assist Module																																								
C	2009	Avalanche	Body	Passenger Door Switch																																								
C	2009	Avalanche	Body	Passenger Presence System																																								
C	2009	Avalanche	Body	Radio																																								
C	2009	Avalanche	Body	Rear Heated Seat Module																																								
C	2009	Avalanche	Body	Rear HVAC/RSA																																								
C	2009	Avalanche	Body	Rollover Sensor																																								
C	2009	Avalanche	Body	Supplemental Inflatable Restraint																																								
C	2009	Avalanche	Body	Theft Deterrent Module																																								
C	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
C	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
C	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																								
C	2009	Cheyenne	Chassis	Trailer Brake Control Module																																								
C	2009	Cheyenne	Body	Amplifier (Bose)																																								
C	2009	Cheyenne	Body	Body Control Module (aux.)																																								
C	2009	Cheyenne	Body	Digital Radio Receiver																																								
C	2009	Cheyenne	Body	Driver Door Switch																																								
C	2009	Cheyenne	Body	Instrument Panel Cluster																																								
C	2009	Cheyenne	Body	Park Assist Module																																								
C	2009	Cheyenne	Body	Passenger Door Switch																																								
C	2009	Cheyenne	Body	Passenger Presence System																																								
C	2009	Cheyenne	Body	Rear Heated Seat Module																																								
C	2009	Cheyenne	Body	Rear HVAC/RSA																																								
C	2009	Cheyenne	Body	Rollover Sensor																																								
C	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																								
C	2009	Cheyenne	Body	Theft Deterrent Module																																								
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
C	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2009	Suburban	Chassis	EBCM Under 8600 GVW																																								
C	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2009	Suburban	Chassis	Electronic Suspension Control																																								
C	2009	Suburban	Chassis	Trailer Brake Control Module																																								
C	2009	Suburban	Body	Amplifier (Bose)																																								
C	2009	Suburban	Body	Assist Step Controller																																								
C	2009	Suburban	Body	Body Control Module																																								
C	2009	Suburban	Body	Body Control Module (aux.)																																								
C	2009	Suburban	Body	Digital Radio Receiver																																								
C	2009	Suburban	Body	Driver Door Switch																																								
C	2009	Suburban	Body	HVAC Control Module Auto																																								
C	2009	Suburban	Body	HVAC Control Module Manual																																								
C	2009	Suburban	Body	Instrument Panel Cluster																																								
C	2009	Suburban	Body	Left Side Object Detection Module																																								
C	2009	Suburban	Body	Lift Gate Module																																								
C	2009	Suburban	Body	Memory Seat Module																																								
C	2009	Suburban	Body	Park Assist Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2009	Suburban	Body	Passenger Door Switch																																								
C	2009	Suburban	Body	Passenger Presence System																																								
C	2009	Suburban	Body	Radio																																								
C	2009	Suburban	Body	Rear Heated Seat Module																																								
C	2009	Suburban	Body	Rear HVAC/RSA																																								
C	2009	Suburban	Body	Right Side Object Detection Module																																								
C	2009	Suburban	Body	Rollover Sensor																																								
C	2009	Suburban	Body	Supplemental Inflatable Restraint																																								
C	2009	Suburban	Body	Theft Deterrent Module																																								
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
C	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																								
C	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																								
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																								
C	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																								
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
C	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																								
C	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
C	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
C	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
C	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																								
C	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
C	2009	Silverado	Chassis	Electronic Suspension Control																																								
C	2009	Silverado	Chassis	Trailer Brake Control Module																																								
C	2009	Silverado	Body	Amplifier (Bose)																																								
C	2009	Silverado	Body	Body Control Module																																								
C	2009	Silverado	Body	Body Control Module (aux.)																																								
C	2009	Silverado	Body	Digital Radio Receiver																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2009	Silverado	Body	Driver Door Switch																																								
C	2009	Silverado	Body	HVAC Control Module Auto																																								
C	2009	Silverado	Body	HVAC Control Module Manual																																								
C	2009	Silverado	Body	Instrument Panel Cluster																																								
C	2009	Silverado	Body	Memory Seat Module																																								
C	2009	Silverado	Body	Park Assist Module																																								
C	2009	Silverado	Body	Passenger Door Switch																																								
C	2009	Silverado	Body	Passenger Presence System																																								
C	2009	Silverado	Body	Radio																																								
C	2009	Silverado	Body	Rear Heated Seat Module																																								
C	2009	Silverado	Body	Rear HVAC/RSA																																								
C	2009	Silverado	Body	Rollover Sensor																																								
C	2009	Silverado	Body	Supplemental Inflatable Restraint																																								
C	2009	Silverado	Body	Theft Deterrent Module																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
C	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																								
C	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																								
C	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																								
C	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																								
C	2009	Silverado Hybrid	Body	Amplifier (Bose)																																								
C	2009	Silverado Hybrid	Body	Body Control Module																																								
C	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																								
C	2009	Silverado Hybrid	Body	Digital Radio Receiver																																								
C	2009	Silverado Hybrid	Body	Driver Door Switch																																								
C	2009	Silverado Hybrid	Body	HVAC Control Module																																								
C	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																								
C	2009	Silverado Hybrid	Body	Memory Seat Module																																								
C	2009	Silverado Hybrid	Body	Park Assist Module																																								
C	2009	Silverado Hybrid	Body	Passenger Door Switch																																								
C	2009	Silverado Hybrid	Body	Passenger Presence System																																								
C	2009	Silverado Hybrid	Body	Radio																																								
C	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																								
C	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																								
C	2009	Silverado Hybrid	Body	Rollover Sensor																																								
C	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																								
C	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2009	Silverado Hybrid	Body	Theft Deterrent Module																																								
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
C	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2009	Tahoe	Chassis	Electronic Brake Control Module																																								
C	2009	Tahoe	Chassis	Electronic Suspension Control																																								
C	2009	Tahoe	Chassis	Trailer Brake Control Module																																								
C	2009	Tahoe	Body	Amplifier (Bose)																																								
C	2009	Tahoe	Body	Assist Step Controller																																								
C	2009	Tahoe	Body	Body Control Module																																								
C	2009	Tahoe	Body	Body Control Module (aux.)																																								
C	2009	Tahoe	Body	Digital Radio Receiver																																								
C	2009	Tahoe	Body	Driver Door Switch																																								
C	2009	Tahoe	Body	HVAC Control Module Auto																																								
C	2009	Tahoe	Body	HVAC Control Module Manual																																								
C	2009	Tahoe	Body	Instrument Panel Cluster																																								
C	2009	Tahoe	Body	Left Side Object Detection Module																																								
C	2009	Tahoe	Body	Lift Gate Module																																								
C	2009	Tahoe	Body	Memory Seat Module																																								
C	2009	Tahoe	Body	Park Assist Module																																								
C	2009	Tahoe	Body	Passenger Door Switch																																								
C	2009	Tahoe	Body	Passenger Presence System																																								
C	2009	Tahoe	Body	Radio																																								
C	2009	Tahoe	Body	Rear Heated Seat Module																																								
C	2009	Tahoe	Body	Rear HVAC/RSA																																								
C	2009	Tahoe	Body	Right Side Object Detection Module																																								
C	2009	Tahoe	Body	Rollover Sensor																																								
C	2009	Tahoe	Body	Supplemental Inflatable Restraint																																								
C	2009	Tahoe	Body	Theft Deterrent Module																																								
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
C	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																								
C	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																								
C	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																								
C	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																								
C	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																								
C	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																								
C	2009	Tahoe Hybrid	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																								
C	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																								
C	2009	Tahoe Hybrid	Body	Driver Door Switch																																								
C	2009	Tahoe Hybrid	Body	Heated Seat Module																																								
C	2009	Tahoe Hybrid	Body	HVAC Control Module																																								
C	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																								
C	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																								
C	2009	Tahoe Hybrid	Body	Park Assist Module																																								
C	2009	Tahoe Hybrid	Body	Passenger Door Switch																																								
C	2009	Tahoe Hybrid	Body	Passenger Presence System																																								
C	2009	Tahoe Hybrid	Body	Radio																																								
C	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																								
C	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																								
C	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																								
C	2009	Tahoe Hybrid	Body	Rollover Sensor																																								
C	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																								
C	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																								
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2010	Avalanche	Chassis	Electronic Brake Control Module																																								
C	2010	Avalanche	Chassis	Electronic Suspension Control																																								
C	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Avalanche	Body	Amplifier (Bose)																																								
C	2010	Avalanche	Body	Assist Step Controller																																								
C	2010	Avalanche	Body	Body Control Module																																								
C	2010	Avalanche	Body	Body Control Module (aux.)																																								
C	2010	Avalanche	Body	Digital Radio Receiver																																								
C	2010	Avalanche	Body	Driver Door Switch																																								
C	2010	Avalanche	Body	HVAC Control Module Auto																																								
C	2010	Avalanche	Body	HVAC Control Module Manual																																								
C	2010	Avalanche	Body	Instrument Panel Cluster																																								
C	2010	Avalanche	Body	Memory Seat Module																																								
C	2010	Avalanche	Body	Park Assist Module																																								
C	2010	Avalanche	Body	Passenger Door Switch																																								
C	2010	Avalanche	Body	Passenger Presence System																																								
C	2010	Avalanche	Body	Radio																																								
C	2010	Avalanche	Body	Rear Heated Seat Module																																								
C	2010	Avalanche	Body	Rear HVAC/RSA																																								
C	2010	Avalanche	Body	Supplemental Inflatable Restraint																																								
C	2010	Avalanche	Body	Theft Deterrent Module																																								
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																								
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
C	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																								
C	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Cheyenne	Body	Amplifier (Bose)																																								
C	2010	Cheyenne	Body	Body Control Module (aux.)																																								
C	2010	Cheyenne	Body	Digital Radio Receiver																																								
C	2010	Cheyenne	Body	Driver Door Switch																																								
C	2010	Cheyenne	Body	Instrument Panel Cluster																																								
C	2010	Cheyenne	Body	Park Assist Module																																								
C	2010	Cheyenne	Body	Passenger Door Switch																																								
C	2010	Cheyenne	Body	Passenger Presence System																																								
C	2010	Cheyenne	Body	Rear Heated Seat Module																																								
C	2010	Cheyenne	Body	Rear HVAC/RSA																																								
C	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																								
C	2010	Cheyenne	Body	Theft Deterrent Module																																								
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
C	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2010	Suburban	Chassis	EBCM Under 8600 GVW																																								
C	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2010	Suburban	Chassis	Electronic Suspension Control																																								
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Suburban	Body	Amplifier (Bose)																																								
C	2010	Suburban	Body	Assist Step Controller																																								
C	2010	Suburban	Body	Body Control Module																																								
C	2010	Suburban	Body	Body Control Module (aux.)																																								
C	2010	Suburban	Body	Digital Radio Receiver																																								
C	2010	Suburban	Body	Driver Door Switch																																								
C	2010	Suburban	Body	HVAC Control Module Auto																																								
C	2010	Suburban	Body	HVAC Control Module Manual																																								
C	2010	Suburban	Body	Instrument Panel Cluster																																								
C	2010	Suburban	Body	Left Side Object Detection Module																																								
C	2010	Suburban	Body	Lift Gate Module																																								
C	2010	Suburban	Body	Memory Seat Module																																								
C	2010	Suburban	Body	Park Assist Module																																								
C	2010	Suburban	Body	Passenger Door Switch																																								
C	2010	Suburban	Body	Passenger Presence System																																								
C	2010	Suburban	Body	Radio																																								
C	2010	Suburban	Body	Rear Heated Seat Module																																								
C	2010	Suburban	Body	Rear HVAC/RSA																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2010	Suburban	Body	Right Side Object Detection Module																																								
C	2010	Suburban	Body	Supplemental Inflatable Restraint																																								
C	2010	Suburban	Body	Theft Deterrent Module																																								
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																								
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																								
C	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
C	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
C	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																								
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																								
C	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
C	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
C	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																								
C	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
C	2010	Silverado	Chassis	Electronic Suspension Control																																								
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																								
C	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																								
C	2010	Silverado	Body	Amplifier (Bose)																																								
C	2010	Silverado	Body	Body Control Module																																								
C	2010	Silverado	Body	Body Control Module (aux.)																																								
C	2010	Silverado	Body	Digital Radio Receiver																																								
C	2010	Silverado	Body	Driver Door Switch																																								
C	2010	Silverado	Body	HVAC Control Module Auto																																								
C	2010	Silverado	Body	HVAC Control Module Manual																																								
C	2010	Silverado	Body	Instrument Panel Cluster																																								
C	2010	Silverado	Body	Memory Seat Module																																								
C	2010	Silverado	Body	Park Assist Module																																								
C	2010	Silverado	Body	Passenger Door Switch																																								
C	2010	Silverado	Body	Passenger Presence System																																								
C	2010	Silverado	Body	Radio																																								
C	2010	Silverado	Body	Rear Heated Seat Module																																								
C	2010	Silverado	Body	Rear HVAC/RSA																																								
C	2010	Silverado	Body	Supplemental Inflatable Restraint																																								
C	2010	Silverado	Body	Theft Deterrent Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
C	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																								
C	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																								
C	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																								
C	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																								
C	2010	Silverado Hybrid	Body	Amplifier (Bose)																																								
C	2010	Silverado Hybrid	Body	Body Control Module																																								
C	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																								
C	2010	Silverado Hybrid	Body	Digital Radio Receiver																																								
C	2010	Silverado Hybrid	Body	Driver Door Switch																																								
C	2010	Silverado Hybrid	Body	Heated Seat Module																																								
C	2010	Silverado Hybrid	Body	HVAC Control Module																																								
C	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																								
C	2010	Silverado Hybrid	Body	Park Assist Module																																								
C	2010	Silverado Hybrid	Body	Passenger Door Switch																																								
C	2010	Silverado Hybrid	Body	Passenger Presence System																																								
C	2010	Silverado Hybrid	Body	Radio																																								
C	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																								
C	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																								
C	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																								
C	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2010	Silverado Hybrid	Body	Theft Deterrent Module																																								
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2010	Tahoe	Chassis	Electronic Brake Control Module																																								
C	2010	Tahoe	Chassis	Electronic Suspension Control																																								
C	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Tahoe	Body	Amplifier (Bose)																																								
C	2010	Tahoe	Body	Assist Step Controller																																								
C	2010	Tahoe	Body	Body Control Module																																								
C	2010	Tahoe	Body	Body Control Module (aux.)																																								
C	2010	Tahoe	Body	Digital Radio Receiver																																								
C	2010	Tahoe	Body	Driver Door Switch																																								
C	2010	Tahoe	Body	HVAC Control Module Auto																																								
C	2010	Tahoe	Body	HVAC Control Module Manual																																								
C	2010	Tahoe	Body	Instrument Panel Cluster																																								
C	2010	Tahoe	Body	Left Side Object Detection Module																																								
C	2010	Tahoe	Body	Lift Gate Module																																								
C	2010	Tahoe	Body	Memory Seat Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2010	Tahoe	Body	Park Assist Module																																								
C	2010	Tahoe	Body	Passenger Door Switch																																								
C	2010	Tahoe	Body	Passenger Presence System																																								
C	2010	Tahoe	Body	Radio																																								
C	2010	Tahoe	Body	Rear Heated Seat Module																																								
C	2010	Tahoe	Body	Rear HVAC/RSA																																								
C	2010	Tahoe	Body	Right Side Object Detection Module																																								
C	2010	Tahoe	Body	Supplemental Inflatable Restraint																																								
C	2010	Tahoe	Body	Theft Deterrent Module																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
C	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																								
C	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																								
C	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																								
C	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																								
C	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																								
C	2010	Tahoe Hybrid	Body	Body Control Module																																								
C	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																								
C	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																								
C	2010	Tahoe Hybrid	Body	Driver Door Switch																																								
C	2010	Tahoe Hybrid	Body	Heated Seat Module																																								
C	2010	Tahoe Hybrid	Body	HVAC Control Module																																								
C	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																								
C	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																								
C	2010	Tahoe Hybrid	Body	Lift Gate Module																																								
C	2010	Tahoe Hybrid	Body	Park Assist Module																																								
C	2010	Tahoe Hybrid	Body	Passenger Door Switch																																								
C	2010	Tahoe Hybrid	Body	Passenger Presence System																																								
C	2010	Tahoe Hybrid	Body	Radio																																								
C	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																								
C	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																								
C	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																								
C	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																								
C	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																								
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2011	Avalanche	Chassis	Electronic Brake Control Module																																								
C	2011	Avalanche	Chassis	Electronic Suspension Control																																								
C	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2011	Avalanche	Body	Amplifier (Bose)																																								
C	2011	Avalanche	Body	Assist Step Controller																																								
C	2011	Avalanche	Body	Body Control Module																																								
C	2011	Avalanche	Body	Body Control Module (aux.)																																								
C	2011	Avalanche	Body	Digital Radio Receiver																																								
C	2011	Avalanche	Body	Driver Door Switch																																								
C	2011	Avalanche	Body	HVAC Control Module Auto																																								
C	2011	Avalanche	Body	HVAC Control Module Manual																																								
C	2011	Avalanche	Body	Instrument Panel Cluster																																								
C	2011	Avalanche	Body	Memory Seat Module																																								
C	2011	Avalanche	Body	Park Assist Module																																								
C	2011	Avalanche	Body	Passenger Door Switch																																								
C	2011	Avalanche	Body	Passenger Presence System																																								
C	2011	Avalanche	Body	Radio																																								
C	2011	Avalanche	Body	Rear Heated Seat Module																																								
C	2011	Avalanche	Body	Rear HVAC/RSA																																								
C	2011	Avalanche	Body	Supplemental Inflatable Restraint																																								
C	2011	Avalanche	Body	Theft Deterrent Module																																								
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
C	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
C	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																								
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																								
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																								
C	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																								
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																								
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																								
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																								
C	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																								
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																								
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																								
C	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																								
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																								
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																								
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																								
C	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																								
C	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																								
C	2011	Captiva	Chassis	Electronic Brake Control Module																																								
C	2011	Captiva	Chassis	Parking Brake Control Module																																								
C	2011	Captiva	Body	Body Control Module																																								
C	2011	Captiva	Body	Auxiliary Body Control Module																																								
C	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2011	Captiva	Body	Instrument Cluster																																								
C	2011	Captiva	Body	Headlamp Control Module																																								
C	2011	Captiva	Body	HVAC Control Module																																								
C	2011	Captiva	Body	Remote Control Door Lock Receiver																																								
C	2011	Captiva	Body	Parking Assist Control Module																																								
C	2011	Captiva	Body	Theft Deterrent Module																																								
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																								
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
C	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																								
C	2011	Cheyenne	Chassis	Electronic Suspension Control																																								
C	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																								
C	2011	Cheyenne	Body	Amplifier (Bose)																																								
C	2011	Cheyenne	Body	Body Control Module																																								
C	2011	Cheyenne	Body	Body Control Module (aux.)																																								
C	2011	Cheyenne	Body	Digital Radio Receiver																																								
C	2011	Cheyenne	Body	Driver Door Switch																																								
C	2011	Cheyenne	Body	Instrument Panel Cluster																																								
C	2011	Cheyenne	Body	Park Assist Module																																								
C	2011	Cheyenne	Body	Passenger Door Switch																																								
C	2011	Cheyenne	Body	Passenger Presence System																																								
C	2011	Cheyenne	Body	Rear Heated Seat Module																																								
C	2011	Cheyenne	Body	Rear HVAC/RSA																																								
C	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																								
C	2011	Cheyenne	Body	Theft Deterrent Module																																								
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
C	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
C	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2011	Suburban	Chassis	EBCM Under 8600 GVW																																								
C	2011	Suburban	Chassis	Electronic Suspension Control																																								
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																								
C	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																								
C	2011	Suburban	Body	Amplifier (Bose)																																								
C	2011	Suburban	Body	Assist Step Controller																																								
C	2011	Suburban	Body	Body Control Module																																								
C	2011	Suburban	Body	Body Control Module (aux.)																																								
C	2011	Suburban	Body	Digital Radio Receiver																																								
C	2011	Suburban	Body	Driver Door Switch																																								
C	2011	Suburban	Body	HVAC Control Module Auto																																								
C	2011	Suburban	Body	HVAC Control Module Manual																																								
C	2011	Suburban	Body	Instrument Panel Cluster																																								
C	2011	Suburban	Body	Left Side Object Detection Module																																								
C	2011	Suburban	Body	Lift Gate Module																																								
C	2011	Suburban	Body	Memory Seat Module																																								
C	2011	Suburban	Body	Park Assist Module																																								
C	2011	Suburban	Body	Passenger Door Switch																																								
C	2011	Suburban	Body	Passenger Presence System																																								
C	2011	Suburban	Body	Radio																																								
C	2011	Suburban	Body	Rear Heated Seat Module																																								
C	2011	Suburban	Body	Rear HVAC/RSA																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2011	Suburban	Body	Right Side Object Detection Module																																								
C	2011	Suburban	Body	Supplemental Inflatable Restraint																																								
C	2011	Suburban	Body	Theft Deterrent Module																																								
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																								
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																								
C	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
C	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																								
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																								
C	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																								
C	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																								
C	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
C	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																								
C	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
C	2011	Silverado	Chassis	Electronic Suspension Control																																								
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																								
C	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																								
C	2011	Silverado	Body	Amplifier (Bose)																																								
C	2011	Silverado	Body	Body Control Module																																								
C	2011	Silverado	Body	Body Control Module (aux.)																																								
C	2011	Silverado	Body	Digital Radio Receiver																																								
C	2011	Silverado	Body	Driver Door Switch																																								
C	2011	Silverado	Body	HVAC Control Module Auto																																								
C	2011	Silverado	Body	HVAC Control Module Manual																																								
C	2011	Silverado	Body	Instrument Panel Cluster																																								
C	2011	Silverado	Body	Memory Seat Module																																								
C	2011	Silverado	Body	Park Assist Module																																								
C	2011	Silverado	Body	Passenger Door Switch																																								
C	2011	Silverado	Body	Passenger Presence System																																								
C	2011	Silverado	Body	Radio																																								
C	2011	Silverado	Body	Rear Heated Seat Module																																								
C	2011	Silverado	Body	Rear HVAC/RSA																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2011	Silverado	Body	Supplemental Inflatable Restraint																																								
C	2011	Silverado	Body	Theft Deterrent Module																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
C	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																								
C	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																								
C	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																								
C	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																								
C	2011	Silverado Hybrid	Body	Amplifier (Bose)																																								
C	2011	Silverado Hybrid	Body	Body Control Module																																								
C	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																								
C	2011	Silverado Hybrid	Body	Digital Radio Receiver																																								
C	2011	Silverado Hybrid	Body	Driver Door Switch																																								
C	2011	Silverado Hybrid	Body	Heated Seat Module																																								
C	2011	Silverado Hybrid	Body	HVAC Control Module																																								
C	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																								
C	2011	Silverado Hybrid	Body	Park Assist Module																																								
C	2011	Silverado Hybrid	Body	Passenger Door Switch																																								
C	2011	Silverado Hybrid	Body	Passenger Presence System																																								
C	2011	Silverado Hybrid	Body	Radio																																								
C	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																								
C	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																								
C	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																								
C	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2011	Silverado Hybrid	Body	Theft Deterrent Module																																								
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2011	Tahoe	Chassis	Electronic Brake Control Module																																								
C	2011	Tahoe	Chassis	Electronic Suspension Control																																								
C	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																								
C	2011	Tahoe	Body	Amplifier (Bose)																																								
C	2011	Tahoe	Body	Assist Step Controller																																								
C	2011	Tahoe	Body	Body Control Module																																								
C	2011	Tahoe	Body	Body Control Module (aux.)																																								
C	2011	Tahoe	Body	Digital Radio Receiver																																								
C	2011	Tahoe	Body	Driver Door Switch																																								
C	2011	Tahoe	Body	HVAC Control Module Auto																																								
C	2011	Tahoe	Body	HVAC Control Module Manual																																								
C	2011	Tahoe	Body	Instrument Panel Cluster																																								
C	2011	Tahoe	Body	Left Side Object Detection Module																																								
C	2011	Tahoe	Body	Lift Gate Module																																								
C	2011	Tahoe	Body	Memory Seat Module																																								
C	2011	Tahoe	Body	Park Assist Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2011	Tahoe	Body	Passenger Door Switch																																								
C	2011	Tahoe	Body	Passenger Presence System																																								
C	2011	Tahoe	Body	Radio																																								
C	2011	Tahoe	Body	Rear Heated Seat Module																																								
C	2011	Tahoe	Body	Rear HVAC/RSA																																								
C	2011	Tahoe	Body	Right Side Object Detection Module																																								
C	2011	Tahoe	Body	Supplemental Inflatable Restraint																																								
C	2011	Tahoe	Body	Theft Deterrent Module																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
C	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																								
C	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																								
C	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																								
C	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																								
C	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																								
C	2011	Tahoe Hybrid	Body	Body Control Module																																								
C	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																								
C	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																								
C	2011	Tahoe Hybrid	Body	Driver Door Switch																																								
C	2011	Tahoe Hybrid	Body	Heated Seat Module																																								
C	2011	Tahoe Hybrid	Body	HVAC Control Module																																								
C	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																								
C	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																								
C	2011	Tahoe Hybrid	Body	Lift Gate Module																																								
C	2011	Tahoe Hybrid	Body	Park Assist Module																																								
C	2011	Tahoe Hybrid	Body	Passenger Door Switch																																								
C	2011	Tahoe Hybrid	Body	Passenger Presence System																																								
C	2011	Tahoe Hybrid	Body	Radio																																								
C	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																								
C	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																								
C	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																								
C	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																								
C	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																								
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
C	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2012	Avalanche	Chassis	Electronic Brake Control Module																																								
C	2012	Avalanche	Chassis	Electronic Suspension Control																																								
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																								
C	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2012	Avalanche	Body	Amplifier (Bose)																																								
C	2012	Avalanche	Body	Assist Step Controller																																								
C	2012	Avalanche	Body	Body Control Module																																								
C	2012	Avalanche	Body	Body Control Module (aux.)																																								
C	2012	Avalanche	Body	Digital Radio Receiver																																								
C	2012	Avalanche	Body	Driver Door Switch																																								
C	2012	Avalanche	Body	HVAC Control Module Auto																																								
C	2012	Avalanche	Body	HVAC Control Module Manual																																								
C	2012	Avalanche	Body	Instrument Panel Cluster																																								
C	2012	Avalanche	Body	Memory Seat Module																																								
C	2012	Avalanche	Body	Navigation Radio																																								
C	2012	Avalanche	Body	Park Assist Module																																								
C	2012	Avalanche	Body	Passenger Door Switch																																								
C	2012	Avalanche	Body	Passenger Presence System																																								
C	2012	Avalanche	Body	Radio																																								
C	2012	Avalanche	Body	Rear Heated Seat Module																																								
C	2012	Avalanche	Body	Rear HVAC/RSA																																								
C	2012	Avalanche	Body	Supplemental Inflatable Restraint																																								
C	2012	Avalanche	Body	Theft Deterrent Module																																								
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
C	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
C	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																								
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																								
C	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																								
C	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																								
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																								
C	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																								
C	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																								
C	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																								
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																								
C	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																								
C	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																								
C	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																								
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																								
C	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																								
C	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																								
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																								
C	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																								
C	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																								
C	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
C	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																								
C	2012	Captiva	Chassis	Electronic Brake Control Module																																								
C	2012	Captiva	Chassis	Parking Brake Control Module																																								
C	2012	Captiva	Body	Body Control Module																																								
C	2012	Captiva	Body	Auxiliary Body Control Module																																								
C	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2012	Captiva	Body	Instrument Cluster																																								
C	2012	Captiva	Body	Headlamp Control Module																																								
C	2012	Captiva	Body	HVAC Control Module																																								
C	2012	Captiva	Body	Remote Control Door Lock Receiver																																								
C	2012	Captiva	Body	Parking Assist Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2012	Captiva	Body	Theft Deterrent Module																																								
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																								
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																								
C	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
C	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
C	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																								
C	2012	Cheyenne	Chassis	Electronic Suspension Control																																								
C	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																								
C	2012	Cheyenne	Body	Amplifier (Bose)																																								
C	2012	Cheyenne	Body	Body Control Module																																								
C	2012	Cheyenne	Body	Body Control Module (aux.)																																								
C	2012	Cheyenne	Body	Digital Radio Receiver																																								
C	2012	Cheyenne	Body	Driver Door Switch																																								
C	2012	Cheyenne	Body	Instrument Panel Cluster																																								
C	2012	Cheyenne	Body	Park Assist Module																																								
C	2012	Cheyenne	Body	Passenger Door Switch																																								
C	2012	Cheyenne	Body	Passenger Presence System																																								
C	2012	Cheyenne	Body	Rear Heated Seat Module																																								
C	2012	Cheyenne	Body	Rear HVAC/RSA																																								
C	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																								
C	2012	Cheyenne	Body	Theft Deterrent Module																																								
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
C	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																								
C	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
C	2012	Suburban	Chassis	EBCM Under 8600 GVW																																								
C	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2012	Suburban	Chassis	Electronic Suspension Control																																								
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																								
C	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																								
C	2012	Suburban	Body	Amplifier (Bose)																																								
C	2012	Suburban	Body	Assist Step Controller																																								
C	2012	Suburban	Body	Body Control Module																																								
C	2012	Suburban	Body	Body Control Module (aux.)																																								
C	2012	Suburban	Body	Digital Radio Receiver																																								
C	2012	Suburban	Body	Driver Door Switch																																								
C	2012	Suburban	Body	HVAC Control Module Auto																																								
C	2012	Suburban	Body	HVAC Control Module Manual																																								
C	2012	Suburban	Body	Instrument Panel Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2012	Suburban	Body	Left Side Object Detection Module																																								
C	2012	Suburban	Body	Lift Gate Module																																								
C	2012	Suburban	Body	Memory Seat Module																																								
C	2012	Suburban	Body	Navigation Radio																																								
C	2012	Suburban	Body	Park Assist Module																																								
C	2012	Suburban	Body	Passenger Door Switch																																								
C	2012	Suburban	Body	Passenger Presence System																																								
C	2012	Suburban	Body	Radio																																								
C	2012	Suburban	Body	Rear Heated Seat Module																																								
C	2012	Suburban	Body	Rear HVAC/RSA																																								
C	2012	Suburban	Body	Right Side Object Detection Module																																								
C	2012	Suburban	Body	Supplemental Inflatable Restraint																																								
C	2012	Suburban	Body	Theft Deterrent Module																																								
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																								
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																								
C	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
C	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																								
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																								
C	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																								
C	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																								
C	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
C	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																								
C	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
C	2012	Silverado	Chassis	Electronic Suspension Control																																								
C	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																								
C	2012	Silverado	Body	Amplifier (Bose)																																								
C	2012	Silverado	Body	Body Control Module																																								
C	2012	Silverado	Body	Body Control Module (aux.)																																								
C	2012	Silverado	Body	Digital Radio Receiver																																								
C	2012	Silverado	Body	Driver Door Switch																																								
C	2012	Silverado	Body	HVAC Control Module Auto																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2012	Silverado	Body	HVAC Control Module Manual																																								
C	2012	Silverado	Body	Instrument Panel Cluster																																								
C	2012	Silverado	Body	Memory Seat Module																																								
C	2012	Silverado	Body	Navigation Radio																																								
C	2012	Silverado	Body	Park Assist Module																																								
C	2012	Silverado	Body	Passenger Door Switch																																								
C	2012	Silverado	Body	Passenger Presence System																																								
C	2012	Silverado	Body	Radio																																								
C	2012	Silverado	Body	Rear Heated Seat Module																																								
C	2012	Silverado	Body	Rear HVAC/RSA																																								
C	2012	Silverado	Body	Supplemental Inflatable Restraint																																								
C	2012	Silverado	Body	Theft Deterrent Module																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
C	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																								
C	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																								
C	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																								
C	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																								
C	2012	Silverado Hybrid	Body	Amplifier (Bose)																																								
C	2012	Silverado Hybrid	Body	Body Control Module																																								
C	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																								
C	2012	Silverado Hybrid	Body	Digital Radio Receiver																																								
C	2012	Silverado Hybrid	Body	Driver Door Switch																																								
C	2012	Silverado Hybrid	Body	Heated Seat Module																																								
C	2012	Silverado Hybrid	Body	HVAC Control Module																																								
C	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																								
C	2012	Silverado Hybrid	Body	Navigation Radio																																								
C	2012	Silverado Hybrid	Body	Park Assist Module																																								
C	2012	Silverado Hybrid	Body	Passenger Door Switch																																								
C	2012	Silverado Hybrid	Body	Passenger Presence System																																								
C	2012	Silverado Hybrid	Body	Radio																																								
C	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																								
C	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																								
C	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																								
C	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2012	Silverado Hybrid	Body	Theft Deterrent Module																																								
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2012	Tahoe	Chassis	Electronic Brake Control Module																																								
C	2012	Tahoe	Chassis	Electronic Suspension Control																																								
C	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																								
C	2012	Tahoe	Body	Amplifier (Bose)																																								
C	2012	Tahoe	Body	Assist Step Controller																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2012	Tahoe	Body	Body Control Module																																								
C	2012	Tahoe	Body	Body Control Module (aux.)																																								
C	2012	Tahoe	Body	Digital Radio Receiver																																								
C	2012	Tahoe	Body	Driver Door Switch																																								
C	2012	Tahoe	Body	HVAC Control Module Auto																																								
C	2012	Tahoe	Body	HVAC Control Module Manual																																								
C	2012	Tahoe	Body	Instrument Panel Cluster																																								
C	2012	Tahoe	Body	Left Side Object Detection Module																																								
C	2012	Tahoe	Body	Lift Gate Module																																								
C	2012	Tahoe	Body	Memory Seat Module																																								
C	2012	Tahoe	Body	Navigation Radio																																								
C	2012	Tahoe	Body	Park Assist Module																																								
C	2012	Tahoe	Body	Passenger Door Switch																																								
C	2012	Tahoe	Body	Passenger Presence System																																								
C	2012	Tahoe	Body	Radio																																								
C	2012	Tahoe	Body	Rear Heated Seat Module																																								
C	2012	Tahoe	Body	Rear HVAC/RSA																																								
C	2012	Tahoe	Body	Right Side Object Detection Module																																								
C	2012	Tahoe	Body	Supplemental Inflatable Restraint																																								
C	2012	Tahoe	Body	Theft Deterrent Module																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
C	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																								
C	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																								
C	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																								
C	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																								
C	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																								
C	2012	Tahoe Hybrid	Body	Body Control Module																																								
C	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																								
C	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																								
C	2012	Tahoe Hybrid	Body	Driver Door Switch																																								
C	2012	Tahoe Hybrid	Body	Heated Seat Module																																								
C	2012	Tahoe Hybrid	Body	HVAC Control Module																																								
C	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																								
C	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																								
C	2012	Tahoe Hybrid	Body	Lift Gate Module																																								
C	2012	Tahoe Hybrid	Body	Navigation Radio																																								
C	2012	Tahoe Hybrid	Body	Park Assist Module																																								
C	2012	Tahoe Hybrid	Body	Passenger Door Switch																																								
C	2012	Tahoe Hybrid	Body	Passenger Presence System																																								
C	2012	Tahoe Hybrid	Body	Radio																																								
C	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																								
C	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																								
C	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																								
C	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																								
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
C	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2013	Avalanche	Chassis	Electronic Brake Control Module																																								
C	2013	Avalanche	Chassis	Electronic Suspension Control																																								
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																								
C	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																								
C	2013	Avalanche	Body	Amplifier (Bose)																																								
C	2013	Avalanche	Body	Assist Step Controller																																								
C	2013	Avalanche	Body	Body Control Module																																								
C	2013	Avalanche	Body	Body Control Module (aux.)																																								
C	2013	Avalanche	Body	Digital Radio Receiver																																								
C	2013	Avalanche	Body	Driver Door Switch																																								
C	2013	Avalanche	Body	HVAC Control Module Auto																																								
C	2013	Avalanche	Body	HVAC Control Module Manual																																								
C	2013	Avalanche	Body	Instrument Panel Cluster																																								
C	2013	Avalanche	Body	Memory Seat Module																																								
C	2013	Avalanche	Body	Navigation Radio																																								
C	2013	Avalanche	Body	Park Assist Module																																								
C	2013	Avalanche	Body	Passenger Door Switch																																								
C	2013	Avalanche	Body	Passenger Presence System																																								
C	2013	Avalanche	Body	Radio																																								
C	2013	Avalanche	Body	Rear Heated Seat Module																																								
C	2013	Avalanche	Body	Rear HVAC/RSA																																								
C	2013	Avalanche	Body	Supplemental Inflatable Restraint																																								
C	2013	Avalanche	Body	Theft Deterrent Module																																								
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
C	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
C	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																								
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																								
C	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																								
C	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																								
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																								
C	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																								
C	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																								
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																								
C	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																								
C	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																								
C	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																								
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																								
C	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																								
C	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
C	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																								
C	2013	Captiva	Chassis	Electronic Brake Control Module																																								
C	2013	Captiva	Chassis	Parking Brake Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																								
C	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																								
C	2013	Captiva	Body	Auxiliary Body Control Module																																								
C	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2013	Captiva	Body	Instrument Cluster																																								
C	2013	Captiva	Body	Headlamp Control Module																																								
C	2013	Captiva	Body	HVAC Control Module																																								
C	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																								
C	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																								
C	2013	Captiva	Body	Theft Deterrent Module																																								
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																								
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																								
C	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
C	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
C	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																								
C	2013	Cheyenne	Chassis	Electronic Suspension Control																																								
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																								
C	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																								
C	2013	Cheyenne	Body	Amplifier (Bose)																																								
C	2013	Cheyenne	Body	Body Control Module																																								
C	2013	Cheyenne	Body	Body Control Module (aux.)																																								
C	2013	Cheyenne	Body	Digital Radio Receiver																																								
C	2013	Cheyenne	Body	Driver Door Switch																																								
C	2013	Cheyenne	Body	Instrument Panel Cluster																																								
C	2013	Cheyenne	Body	Park Assist Module																																								
C	2013	Cheyenne	Body	Passenger Door Switch																																								
C	2013	Cheyenne	Body	Passenger Presence System																																								
C	2013	Cheyenne	Body	Rear Heated Seat Module																																								
C	2013	Cheyenne	Body	Rear HVAC/RSA																																								
C	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																								
C	2013	Cheyenne	Body	Theft Deterrent Module																																								
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
C	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																								
C	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
C	2013	Suburban	Chassis	EBCM Under 8600 GVW																																								
C	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2013	Suburban	Chassis	Electronic Suspension Control																																								
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																								
C	2013	Suburban	Body	Amplifier (Bose)																																								
C	2013	Suburban	Body	Assist Step Controller																																								
C	2013	Suburban	Body	Body Control Module																																								
C	2013	Suburban	Body	Body Control Module (aux.)																																								
C	2013	Suburban	Body	Digital Radio Receiver																																								
C	2013	Suburban	Body	Driver Door Switch																																								
C	2013	Suburban	Body	HVAC Control Module Auto																																								
C	2013	Suburban	Body	HVAC Control Module Manual																																								
C	2013	Suburban	Body	Instrument Panel Cluster																																								
C	2013	Suburban	Body	Left Side Object Detection Module																																								
C	2013	Suburban	Body	Lift Gate Module																																								
C	2013	Suburban	Body	Memory Seat Module																																								
C	2013	Suburban	Body	Navigation Radio																																								
C	2013	Suburban	Body	Park Assist Module																																								
C	2013	Suburban	Body	Passenger Door Switch																																								
C	2013	Suburban	Body	Passenger Presence System																																								
C	2013	Suburban	Body	Radio																																								
C	2013	Suburban	Body	Rear Heated Seat Module																																								
C	2013	Suburban	Body	Rear HVAC/RSA																																								
C	2013	Suburban	Body	Right Side Object Detection Module																																								
C	2013	Suburban	Body	Supplemental Inflatable Restraint																																								
C	2013	Suburban	Body	Theft Deterrent Module																																								
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																								
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																								
C	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
C	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																								
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																								
C	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																								
C	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																								
C	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								
C	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
C	2013	Silverado	Chassis	Electronic Suspension Control																																								
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																								
C	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																								
C	2013	Silverado	Body	Amplifier (Bose)																																								
C	2013	Silverado	Body	Body Control Module																																								
C	2013	Silverado	Body	Body Control Module (aux.)																																								
C	2013	Silverado	Body	Digital Radio Receiver																																								
C	2013	Silverado	Body	Driver Door Switch																																								
C	2013	Silverado	Body	HVAC Control Module Auto																																								
C	2013	Silverado	Body	HVAC Control Module Manual																																								
C	2013	Silverado	Body	Instrument Panel Cluster																																								
C	2013	Silverado	Body	Memory Seat Module																																								
C	2013	Silverado	Body	Navigation Radio																																								
C	2013	Silverado	Body	Park Assist Module																																								
C	2013	Silverado	Body	Passenger Door Switch																																								
C	2013	Silverado	Body	Passenger Presence System																																								
C	2013	Silverado	Body	Radio																																								
C	2013	Silverado	Body	Rear Heated Seat Module																																								
C	2013	Silverado	Body	Rear HVAC/RSA																																								
C	2013	Silverado	Body	Supplemental Inflatable Restraint																																								
C	2013	Silverado	Body	Theft Deterrent Module																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
C	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																								
C	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																								
C	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																								
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																								
C	2013	Silverado Hybrid	Body	Amplifier (Bose)																																								
C	2013	Silverado Hybrid	Body	Body Control Module																																								
C	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																								
C	2013	Silverado Hybrid	Body	Digital Radio Receiver																																								
C	2013	Silverado Hybrid	Body	Driver Door Switch																																								
C	2013	Silverado Hybrid	Body	Heated Seat Module																																								
C	2013	Silverado Hybrid	Body	HVAC Control Module																																								
C	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																								
C	2013	Silverado Hybrid	Body	Navigation Radio																																								
C	2013	Silverado Hybrid	Body	Park Assist Module																																								
C	2013	Silverado Hybrid	Body	Passenger Door Switch																																								
C	2013	Silverado Hybrid	Body	Passenger Presence System																																								
C	2013	Silverado Hybrid	Body	Radio																																								
C	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																								
C	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																								
C	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2013	Silverado Hybrid	Body	Theft Deterrent Module																																								
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2013	Tahoe	Chassis	Electronic Brake Control Module																																								
C	2013	Tahoe	Chassis	Electronic Suspension Control																																								
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																								
C	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																								
C	2013	Tahoe	Body	Amplifier (Bose)																																								
C	2013	Tahoe	Body	Assist Step Controller																																								
C	2013	Tahoe	Body	Body Control Module																																								
C	2013	Tahoe	Body	Body Control Module (aux.)																																								
C	2013	Tahoe	Body	Digital Radio Receiver																																								
C	2013	Tahoe	Body	Driver Door Switch																																								
C	2013	Tahoe	Body	HVAC Control Module Auto																																								
C	2013	Tahoe	Body	HVAC Control Module Manual																																								
C	2013	Tahoe	Body	Instrument Panel Cluster																																								
C	2013	Tahoe	Body	Left Side Object Detection Module																																								
C	2013	Tahoe	Body	Lift Gate Module																																								
C	2013	Tahoe	Body	Memory Seat Module																																								
C	2013	Tahoe	Body	Navigation Radio																																								
C	2013	Tahoe	Body	Park Assist Module																																								
C	2013	Tahoe	Body	Passenger Door Switch																																								
C	2013	Tahoe	Body	Passenger Presence System																																								
C	2013	Tahoe	Body	Radio																																								
C	2013	Tahoe	Body	Rear Heated Seat Module																																								
C	2013	Tahoe	Body	Rear HVAC/RSA																																								
C	2013	Tahoe	Body	Right Side Object Detection Module																																								
C	2013	Tahoe	Body	Supplemental Inflatable Restraint																																								
C	2013	Tahoe	Body	Theft Deterrent Module																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
C	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																								
C	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																								
C	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																								
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																								
C	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																								
C	2013	Tahoe Hybrid	Body	Body Control Module																																								
C	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																								
C	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																								
C	2013	Tahoe Hybrid	Body	Driver Door Switch																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2013	Tahoe Hybrid	Body	Heated Seat Module																																								
C	2013	Tahoe Hybrid	Body	HVAC Control Module																																								
C	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																								
C	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																								
C	2013	Tahoe Hybrid	Body	Lift Gate Module																																								
C	2013	Tahoe Hybrid	Body	Navigation Radio																																								
C	2013	Tahoe Hybrid	Body	Park Assist Module																																								
C	2013	Tahoe Hybrid	Body	Passenger Door Switch																																								
C	2013	Tahoe Hybrid	Body	Passenger Presence System																																								
C	2013	Tahoe Hybrid	Body	Radio																																								
C	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																								
C	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																								
C	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																								
C	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																								
C	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																								
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																								
C	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																								
C	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
C	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																								
C	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																								
C	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																								
C	2014	Captiva (3GN)	Body	Body Control Module																																								
C	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2014	Captiva (3GN)	Body	Passenger Presence Module																																								
C	2014	Captiva (3GN)	Body	Instrument Cluster																																								
C	2014	Captiva (3GN)	Body	Radio																																								
C	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																								
C	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																								
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																								
C	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																								
C	2014	Captiva (3GN)	Body	HVAC Control Module																																								
C	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																								
C	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																								
C	2014	Captiva (3GN)	Body	Parking Assist Control Module																																								
C	2014	Captiva (3GN)	Body	Theft Deterrent Module																																								
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
C	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
C	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																								
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																								
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																								
C	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																								
C	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																								
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																								
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
C	2014	Captiva (Other)	Powertrain	Chassis Control Module																																								
C	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																								
C	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																								
C	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																								
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																								
C	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																								
C	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																								
C	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2014	Captiva (Other)	Body	Instrument Cluster																																								
C	2014	Captiva (Other)	Body	Headlamp Control Module																																								
C	2014	Captiva (Other)	Body	HVAC Control Module																																								
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																								
C	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																								
C	2014	Captiva (Other)	Body	Theft Deterrent Module																																								
C	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
C	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																								
C	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																								
C	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																								
C	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
C	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
C	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																								
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
C	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
C	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
C	2014	Cheyenne	Chassis	Electronic Brake Control Module																																								
C	2014	Cheyenne	Chassis	Parking Brake Control Module																																								
C	2014	Cheyenne	Chassis	Power Steering Control Module																																								
C	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																								
C	2014	Cheyenne	Body	Body Control Module																																								
C	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2014	Cheyenne	Body	Passenger Presence Module																																								
C	2014	Cheyenne	Body	Instrument Cluster																																								
C	2014	Cheyenne	Body	Radio Control																																								
C	2014	Cheyenne	Body	HVAC Control																																								
C	2014	Cheyenne	Body	Radio																																								
C	2014	Cheyenne	Body	Amplifier																																								
C	2014	Cheyenne	Body	Media Disc Player																																								
C	2014	Cheyenne	Body	Human Machine Interface Control Module																																								
C	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																								
C	2014	Cheyenne	Body	HVAC Control Module																																								
C	2014	Cheyenne	Body	Left Side Object Detection Control Module																																								
C	2014	Cheyenne	Body	Parking Assist Control Module																																								
C	2014	Cheyenne	Body	Frontview Camera Module																																								
C	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
C	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																								
C	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
C	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																								
C	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
C	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																								
C	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
C	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
C	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																								
C	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
C	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
C	2014	Silverado	Chassis	Electronic Brake Control Module																																								
C	2014	Silverado	Chassis	Parking Brake Control Module																																								
C	2014	Silverado	Chassis	Power Steering Control Module																																								
C	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																								
C	2014	Silverado	Body	Body Control Module																																								
C	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2014	Silverado	Body	Passenger Presence Module																																								
C	2014	Silverado	Body	Instrument Cluster																																								
C	2014	Silverado	Body	Radio Control																																								
C	2014	Silverado	Body	HVAC Control																																								
C	2014	Silverado	Body	Radio																																								
C	2014	Silverado	Body	Amplifier																																								
C	2014	Silverado	Body	Media Disc Player																																								
C	2014	Silverado	Body	Human Machine Interface Control Module																																								
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																								
C	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																								
C	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																								
C	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																								
C	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																								
C	2014	Silverado	Body	Parking Assist Control Module																																								
C	2014	Silverado	Body	Frontview Camera Module																																								
C	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																								
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																								
C	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																								
C	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																								
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																								
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																								
C	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
C	2014	Silverado HD	Powertrain	Transfer Case Control Module																																								
C	2014	Silverado HD	Chassis	Electronic Brake Control Module																																								
C	2014	Silverado HD	Chassis	Trailer Brake Control Module																																								
C	2014	Silverado HD	Chassis	Suspension Control Module																																								
C	2014	Silverado HD	Body	Body Control Module																																								
C	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2014	Silverado HD	Body	Passenger Presence Module																																								
C	2014	Silverado HD	Body	Instrument Cluster																																								
C	2014	Silverado HD	Body	Chime Alarm Control Module																																								
C	2014	Silverado HD	Body	Base Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2014	Silverado HD	Body	Navigation Radio																																								
C	2014	Silverado HD	Body	Uplevel Radio																																								
C	2014	Silverado HD	Body	Amplifier																																								
C	2014	Silverado HD	Body	Rear Audio Control Module																																								
C	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																								
C	2014	Silverado HD	Body	Personal Audio Link Control Module																																								
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																								
C	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																								
C	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																								
C	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																								
C	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																								
C	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																								
C	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																								
C	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																								
C	2014	Silverado HD	Body	Seat Memory Control Module																																								
C	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																								
C	2014	Silverado HD	Body	Parking Assist Control Module																																								
C	2014	Silverado HD	Body	Theft Deterrent Module																																								
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																								
C	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																								
C	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																								
C	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																								
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																								
C	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																								
C	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																								
C	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
C	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
C	2014	Suburban	Chassis	Electronic Brake Control Module																																								
C	2014	Suburban	Chassis	Parking Brake Control Module																																								
C	2014	Suburban	Chassis	Suspension Control Module																																								
C	2014	Suburban	Body	Body Control Module																																								
C	2014	Suburban	Body	Auxiliary Body Control Module																																								
C	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2014	Suburban	Body	Passenger Presence Module																																								
C	2014	Suburban	Body	Instrument Cluster																																								
C	2014	Suburban	Body	Base Radio																																								
C	2014	Suburban	Body	Navigation Radio																																								
C	2014	Suburban	Body	Uplevel Radio																																								
C	2014	Suburban	Body	Amplifier																																								
C	2014	Suburban	Body	Rear Audio Control Module																																								
C	2014	Suburban	Body	Digital Radio Receiver Control Module																																								
C	2014	Suburban	Body	Personal Audio Link Control Module																																								
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																								
C	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																								
C	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																								
C	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																								
C	2014	Suburban	Body	Driver Door Switch Panel Control Module																																								
C	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																								
C	2014	Suburban	Body	Liftgate Control Module																																								
C	2014	Suburban	Body	Seat Memory Control Module																																								
C	2014	Suburban	Body	Rear Seat Heating Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2014	Suburban	Body	Assist Step Control Module																																								
C	2014	Suburban	Body	Right Side Object Detection Control Module																																								
C	2014	Suburban	Body	Left Side Object Detection Control Module																																								
C	2014	Suburban	Body	Remote Control Door Lock Receiver																																								
C	2014	Suburban	Body	Parking Assist Control Module																																								
C	2014	Suburban	Body	Theft Deterrent Module																																								
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																								
C	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																								
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																								
C	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																								
C	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
C	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
C	2014	Tahoe	Chassis	Electronic Brake Control Module																																								
C	2014	Tahoe	Chassis	Parking Brake Control Module																																								
C	2014	Tahoe	Chassis	Suspension Control Module																																								
C	2014	Tahoe	Body	Body Control Module																																								
C	2014	Tahoe	Body	Auxiliary Body Control Module																																								
C	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2014	Tahoe	Body	Passenger Presence Module																																								
C	2014	Tahoe	Body	Instrument Cluster																																								
C	2014	Tahoe	Body	Base Radio																																								
C	2014	Tahoe	Body	Navigation Radio																																								
C	2014	Tahoe	Body	Uplevel Radio																																								
C	2014	Tahoe	Body	Amplifier																																								
C	2014	Tahoe	Body	Rear Audio Control Module																																								
C	2014	Tahoe	Body	Digital Radio Receiver Control Module																																								
C	2014	Tahoe	Body	Personal Audio Link Control Module																																								
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																								
C	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																								
C	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																								
C	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																								
C	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																								
C	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																								
C	2014	Tahoe	Body	Liftgate Control Module																																								
C	2014	Tahoe	Body	Seat Memory Control Module																																								
C	2014	Tahoe	Body	Rear Seat Heating Control Module																																								
C	2014	Tahoe	Body	Assist Step Control Module																																								
C	2014	Tahoe	Body	Right Side Object Detection Control Module																																								
C	2014	Tahoe	Body	Left Side Object Detection Control Module																																								
C	2014	Tahoe	Body	Remote Control Door Lock Receiver																																								
C	2014	Tahoe	Body	Parking Assist Control Module																																								
C	2014	Tahoe	Body	Theft Deterrent Module																																								
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																								
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																								
C	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																								
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																								
C	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
C	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																								
C	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																								
C	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2015	Captiva (3GN)	Body	Body Control Module																																								
C	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2015	Captiva (3GN)	Body	Passenger Presence Module																																								
C	2015	Captiva (3GN)	Body	Instrument Cluster																																								
C	2015	Captiva (3GN)	Body	Radio																																								
C	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																								
C	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																								
C	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																								
C	2015	Captiva (3GN)	Body	HVAC Control Module																																								
C	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																								
C	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																								
C	2015	Captiva (3GN)	Body	Parking Assist Control Module																																								
C	2015	Captiva (3GN)	Body	Theft Deterrent Module																																								
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
C	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
C	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																								
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																								
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																								
C	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																								
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																								
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																								
C	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																								
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																								
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																								
C	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
C	2015	Captiva (Other)	Powertrain	Chassis Control Module																																								
C	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																								
C	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																								
C	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																								
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																								
C	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																								
C	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																								
C	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2015	Captiva (Other)	Body	Instrument Cluster																																								
C	2015	Captiva (Other)	Body	Headlamp Control Module																																								
C	2015	Captiva (Other)	Body	HVAC Control Module																																								
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																								
C	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																								
C	2015	Captiva (Other)	Body	Theft Deterrent Module																																								
C	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
C	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																								
C	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																								
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																								
C	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																								
C	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
C	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
C	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																								
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																								
C	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
C	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
C	2015	Cheyenne	Chassis	Electronic Brake Control Module																																								
C	2015	Cheyenne	Chassis	Power Steering Control Module																																								
C	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																								
C	2015	Cheyenne	Chassis	Suspension Control Module																																								
C	2015	Cheyenne	Body	Body Control Module																																								
C	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2015	Cheyenne	Body	Passenger Presence Module																																								
C	2015	Cheyenne	Body	Instrument Cluster																																								
C	2015	Cheyenne	Body	Radio Controls																																								
C	2015	Cheyenne	Body	HVAC Controls																																								
C	2015	Cheyenne	Body	Radio																																								
C	2015	Cheyenne	Body	Amplifier																																								
C	2015	Cheyenne	Body	Media Disc Player																																								
C	2015	Cheyenne	Body	Human Machine Interface Control Module																																								
C	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																								
C	2015	Cheyenne	Body	HVAC Control Module																																								
C	2015	Cheyenne	Body	Parking Assist Control Module																																								
C	2015	Cheyenne	Body	Frontview Camera Module																																								
C	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
C	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
C	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																								
C	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
C	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																								
C	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																								
C	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
C	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																								
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
C	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																								
C	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
C	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
C	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																								
C	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																								
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																								
C	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
C	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
C	2015	Silverado	Chassis	Electronic Brake Control Module																																								
C	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																								
C	2015	Silverado	Chassis	Power Steering Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																								
C	2015	Silverado	Chassis	Suspension Control Module																																								
C	2015	Silverado	Body	Body Control Module																																								
C	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2015	Silverado	Body	Passenger Presence Module																																								
C	2015	Silverado	Body	Instrument Cluster																																								
C	2015	Silverado	Body	Radio Controls																																								
C	2015	Silverado	Body	HVAC Controls																																								
C	2015	Silverado	Body	Radio																																								
C	2015	Silverado	Body	Amplifier																																								
C	2015	Silverado	Body	Media Disc Player																																								
C	2015	Silverado	Body	Human Machine Interface Control Module																																								
C	2015	Silverado	Body	Telematics Communication Interface Control Module																																								
C	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																								
C	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																								
C	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																								
C	2015	Silverado	Body	Parking Assist Control Module																																								
C	2015	Silverado	Body	Frontview Camera Module																																								
C	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																								
C	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
C	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																								
C	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
C	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																								
C	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																								
C	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																								
C	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
C	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
C	2015	Suburban	Chassis	Electronic Brake Control Module																																								
C	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																								
C	2015	Suburban	Chassis	Parking Brake Control Module																																								
C	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																								
C	2015	Suburban	Chassis	Power Steering Control Module																																								
C	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																								
C	2015	Suburban	Chassis	Suspension Control Module																																								
C	2015	Suburban	Body	Body Control Module																																								
C	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2015	Suburban	Body	Passenger Presence Module																																								
C	2015	Suburban	Body	Instrument Cluster																																								
C	2015	Suburban	Body	Radio Controls																																								
C	2015	Suburban	Body	HVAC Controls																																								
C	2015	Suburban	Body	Radio																																								
C	2015	Suburban	Body	Amplifier																																								
C	2015	Suburban	Body	Media Disc Player																																								
C	2015	Suburban	Body	Human Machine Interface Control Module																																								
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																								
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																								
C	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																								
C	2015	Suburban	Body	HVAC Control Module																																								
C	2015	Suburban	Body	Liftgate Control Module																																								
C	2015	Suburban	Body	Keyless Entry Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2015	Suburban	Body	Assist Step Control Module																																								
C	2015	Suburban	Body	Left Side Object Detection Control Module																																								
C	2015	Suburban	Body	Parking Assist Control Module																																								
C	2015	Suburban	Body	Frontview Camera Module																																								
C	2015	Suburban	Body	Steering Column Lock Control Module																																								
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																								
C	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																								
C	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
C	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																								
C	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																								
C	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																								
C	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
C	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
C	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																								
C	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																								
C	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																								
C	2015	Tahoe	Chassis	Electronic Brake Control Module																																								
C	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																								
C	2015	Tahoe	Chassis	Parking Brake Control Module																																								
C	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																								
C	2015	Tahoe	Chassis	Power Steering Control Module																																								
C	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																								
C	2015	Tahoe	Chassis	Suspension Control Module																																								
C	2015	Tahoe	Body	Body Control Module																																								
C	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2015	Tahoe	Body	Passenger Presence Module																																								
C	2015	Tahoe	Body	Instrument Cluster																																								
C	2015	Tahoe	Body	Radio Controls																																								
C	2015	Tahoe	Body	HVAC Controls																																								
C	2015	Tahoe	Body	Radio																																								
C	2015	Tahoe	Body	Amplifier																																								
C	2015	Tahoe	Body	Media Disc Player																																								
C	2015	Tahoe	Body	Human Machine Interface Control Module																																								
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																								
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																								
C	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																								
C	2015	Tahoe	Body	HVAC Control Module																																								
C	2015	Tahoe	Body	Liftgate Control Module																																								
C	2015	Tahoe	Body	Keyless Entry Control Module																																								
C	2015	Tahoe	Body	Assist Step Control Module																																								
C	2015	Tahoe	Body	Left Side Object Detection Control Module																																								
C	2015	Tahoe	Body	Parking Assist Control Module																																								
C	2015	Tahoe	Body	Frontview Camera Module																																								
C	2015	Tahoe	Body	Steering Column Lock Control Module																																								
C	2015	Tahoe	Body	Battery Energy Control Module																																								
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																								
C	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																								
C	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																								
C	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																								
C	2016	Captiva (3GN)	Body	Body Control Module																																								
C	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2016	Captiva (3GN)	Body	Instrument Cluster																																								
C	2016	Captiva (3GN)	Body	Radio																																								
C	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																								
C	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																								
C	2016	Captiva (3GN)	Body	HVAC Control Module																																								
C	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																								
C	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																								
C	2016	Captiva (3GN)	Body	Parking Assist Control Module																																								
C	2016	Captiva (3GN)	Body	Theft Deterrent Module																																								
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																								
C	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																								
C	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																								
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
C	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
C	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																								
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																								
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																								
C	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																								
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																								
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																								
C	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																								
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																								
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																								
C	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
C	2016	Captiva (Other)	Powertrain	Chassis Control Module																																								
C	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																								
C	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																								
C	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																								
C	2016	Captiva (Other)	Chassis	Power Steering Control Module																																								
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																								
C	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																								
C	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																								
C	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2016	Captiva (Other)	Body	Instrument Cluster																																								
C	2016	Captiva (Other)	Body	Headlamp Control Module																																								
C	2016	Captiva (Other)	Body	Radio																																								
C	2016	Captiva (Other)	Body	HVAC Control Module																																								
C	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																								
C	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																								
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																								
C	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																								
C	2016	Captiva (Other)	Body	Theft Deterrent Module																																								
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																								
C	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																								
C	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
C	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																								
C	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
C	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
C	2016	Cheyenne	Chassis	Electronic Brake Control Module																																								
C	2016	Cheyenne	Chassis	Power Steering Control Module																																								
C	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																								
C	2016	Cheyenne	Chassis	Suspension Control Module																																								
C	2016	Cheyenne	Body	Body Control Module																																								
C	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2016	Cheyenne	Body	Passenger Presence Module																																								
C	2016	Cheyenne	Body	Instrument Cluster																																								
C	2016	Cheyenne	Body	Radio Controls																																								
C	2016	Cheyenne	Body	HVAC Controls																																								
C	2016	Cheyenne	Body	Radio																																								
C	2016	Cheyenne	Body	Amplifier																																								
C	2016	Cheyenne	Body	Media Disc Player																																								
C	2016	Cheyenne	Body	Human Machine Interface Control Module																																								
C	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																								
C	2016	Cheyenne	Body	HVAC Control Module																																								
C	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																								
C	2016	Cheyenne	Body	Parking Assist Control Module																																								
C	2016	Cheyenne	Body	Frontview Camera Module																																								
C	2016	Cheyenne	Body	Frontview Camera Module																																								
C	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
C	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
C	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																								
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																								
C	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																								
C	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																								
C	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																								
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																								
C	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																								
C	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																								
C	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																								
C	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
C	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																								
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
C	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
C	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																								
C	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																								
C	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																								
C	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																								
C	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
C	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
C	2016	Silverado	Chassis	Electronic Brake Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2016	Silverado	Chassis	Power Steering Control Module																																								
C	2016	Silverado	Chassis	Power Steering Control Module																																								
C	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																								
C	2016	Silverado	Chassis	Suspension Control Module																																								
C	2016	Silverado	Body	Body Control Module																																								
C	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2016	Silverado	Body	Passenger Presence Module																																								
C	2016	Silverado	Body	Instrument Cluster																																								
C	2016	Silverado	Body	Radio Controls																																								
C	2016	Silverado	Body	HVAC Controls																																								
C	2016	Silverado	Body	Radio (IO3)																																								
C	2016	Silverado	Body	Radio (IOB)																																								
C	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																								
C	2016	Silverado	Body	Amplifier																																								
C	2016	Silverado	Body	Media Disc Player																																								
C	2016	Silverado	Body	Human Machine Interface Control Module																																								
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																								
C	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																								
C	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																								
C	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																								
C	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																								
C	2016	Silverado	Body	Seat Memory Control Module - Driver																																								
C	2016	Silverado	Body	Assist Step Object Detection Control Module																																								
C	2016	Silverado	Body	Parking Assist Control Module																																								
C	2016	Silverado	Body	Frontview Camera Module																																								
C	2016	Silverado	Body	Frontview Camera Module																																								
C	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																								
C	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
C	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																								
C	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
C	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
C	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
C	2016	Suburban	Chassis	Electronic Brake Control Module																																								
C	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																								
C	2016	Suburban	Chassis	Parking Brake Control Module																																								
C	2016	Suburban	Chassis	Power Steering Control Module																																								
C	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																								
C	2016	Suburban	Chassis	Suspension Control Module																																								
C	2016	Suburban	Body	Body Control Module																																								
C	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2016	Suburban	Body	Passenger Presence Module																																								
C	2016	Suburban	Body	Instrument Cluster																																								
C	2016	Suburban	Body	Radio Controls																																								
C	2016	Suburban	Body	HVAC Controls																																								
C	2016	Suburban	Body	Radio																																								
C	2016	Suburban	Body	Amplifier																																								
C	2016	Suburban	Body	Media Disc Player																																								
C	2016	Suburban	Body	Human Machine Interface Control Module																																								
C	2016	Suburban	Body	Telematics Communication Interface Control Module																																								
C	2016	Suburban	Body	HVAC Control Module																																								
C	2016	Suburban	Body	Liftgate Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2016	Suburban	Body	Seat Memory Control Module - Passenger																																								
C	2016	Suburban	Body	Seat Memory Control Module - Driver																																								
C	2016	Suburban	Body	Keyless Entry Control Module																																								
C	2016	Suburban	Body	Assist Step Control Module																																								
C	2016	Suburban	Body	Left Side Object Detection Control Module																																								
C	2016	Suburban	Body	Parking Assist Control Module																																								
C	2016	Suburban	Body	Frontview Camera Module																																								
C	2016	Suburban	Body	Steering Column Lock Control Module																																								
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																								
C	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
C	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
C	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
C	2016	Tahoe	Chassis	Electronic Brake Control Module																																								
C	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																								
C	2016	Tahoe	Chassis	Parking Brake Control Module																																								
C	2016	Tahoe	Chassis	Power Steering Control Module																																								
C	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																								
C	2016	Tahoe	Chassis	Suspension Control Module																																								
C	2016	Tahoe	Body	Body Control Module																																								
C	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2016	Tahoe	Body	Passenger Presence Module																																								
C	2016	Tahoe	Body	Instrument Cluster																																								
C	2016	Tahoe	Body	Radio Controls																																								
C	2016	Tahoe	Body	HVAC Controls																																								
C	2016	Tahoe	Body	Radio																																								
C	2016	Tahoe	Body	Amplifier																																								
C	2016	Tahoe	Body	Media Disc Player																																								
C	2016	Tahoe	Body	Human Machine Interface Control Module																																								
C	2016	Tahoe	Body	Telematics Communication Interface Control Module																																								
C	2016	Tahoe	Body	HVAC Control Module																																								
C	2016	Tahoe	Body	Liftgate Control Module																																								
C	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																								
C	2016	Tahoe	Body	Seat Memory Control Module - Driver																																								
C	2016	Tahoe	Body	Keyless Entry Control Module																																								
C	2016	Tahoe	Body	Assist Step Control Module																																								
C	2016	Tahoe	Body	Left Side Object Detection Control Module																																								
C	2016	Tahoe	Body	Parking Assist Control Module																																								
C	2016	Tahoe	Body	Frontview Camera Module																																								
C	2016	Tahoe	Body	Steering Column Lock Control Module																																								
E	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																								
E	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																								
E	2004	ALL	Chassis	Electronic Brake Control Module																																								
E	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																								
E	2006	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																								
E	2006	ALL	Chassis	Electronic Brake Control Module																																								
E	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																								
E	2007	ALL	Chassis	Electronic Brake Control Module																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																								
G	2004	Express/Savana	Chassis	VSES																																								
G	2004	Express/Savana	Body	Body Control Module																																								
G	2004	Express/Savana	Body	Instrument Panel Cluster																																								
G	2004	Express/Savana	Body	Multifunction Alarm Module																																								
G	2004	Express/Savana	Body	OnStar																																								
G	2004	Express/Savana	Body	Base Radio																																								
G	2004	Express/Savana	Body	Uplevel Radio																																								
G	2004	Express/Savana	Body	Remote Function Actuation																																								
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																								
G	2004	Express Access/Savana Pro	Chassis	VSES																																								
G	2004	Express Access/Savana Pro	Body	Body Control Module																																								
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
G	2004	Express Access/Savana Pro	Body	OnStar																																								
G	2004	Express Access/Savana Pro	Body	Base Radio																																								
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																								
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																								
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																								
G	2005	Express/Savana	Chassis	VSES																																								
G	2005	Express/Savana	Body	Body Control Module																																								
G	2005	Express/Savana	Body	Instrument Panel Cluster																																								
G	2005	Express/Savana	Body	Multifunction Alarm Module																																								
G	2005	Express/Savana	Body	Base Radio																																								
G	2005	Express/Savana	Body	Uplevel Radio																																								
G	2005	Express/Savana	Body	Remote Function Actuation																																								
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																								
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																								
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																								
G	2005	Express Access/Savana Pro	Chassis	VSES																																								
G	2005	Express Access/Savana Pro	Body	Body Control Module																																								
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
G	2005	Express Access/Savana Pro	Body	Base Radio																																								
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																								
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																								
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																								
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																								
G	2006	Express/Savana	Chassis	VSES																																								
G	2006	Express/Savana	Body	Body Control Module																																								
G	2006	Express/Savana	Body	Instrument Panel Cluster																																								
G	2006	Express/Savana	Body	Multifunction Alarm Module																																								
G	2006	Express/Savana	Body	Passenger Presence System																																								
G	2006	Express/Savana	Body	Base Radio																																								
G	2006	Express/Savana	Body	Uplevel Radio																																								
G	2006	Express/Savana	Body	Remote Function Actuation																																								
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																								
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																								
G	2006	Express Access/Savana Pro	Chassis	VSES																																								
G	2006	Express Access/Savana Pro	Body	Body Control Module																																								
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2006	Express Access/Savana Pro	Body	Base Radio																																								
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																								
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																								
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																								
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
G	2007	Express/Savana	Body	Body Control Module																																								
G	2007	Express/Savana	Body	Instrument Panel Cluster																																								
G	2007	Express/Savana	Body	Multifunction Alarm Module																																								
G	2007	Express/Savana	Body	Passenger Presence System																																								
G	2007	Express/Savana	Body	Base Radio																																								
G	2007	Express/Savana	Body	Uplevel Radio																																								
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																								
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
G	2007	Express Access/Savana Pro	Body	Body Control Module																																								
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2007	Express Access/Savana Pro	Body	Radio																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
G	2008	Express/Savana	Body	Body Control Module																																								
G	2008	Express/Savana	Body	Instrument Panel Cluster																																								
G	2008	Express/Savana	Body	Passenger Presence System																																								
G	2008	Express/Savana	Body	Radio																																								
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																								
G	2008	Express/Savana	Body	Rollover Sensor																																								
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2008	Express/Savana	Body	Theft Deterrent Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
G	2008	Express Access/Savana Pro	Body	Body Control Module																																								
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2008	Express Access/Savana Pro	Body	Radio																																								
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																								
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																								
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
G	2009	Express/Savana	Body	Body Control Module																																								
G	2009	Express/Savana	Body	Instrument Panel Cluster																																								
G	2009	Express/Savana	Body	Passenger Presence System																																								
G	2009	Express/Savana	Body	Radio																																								
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																								
G	2009	Express/Savana	Body	Rollover Sensor																																								
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2009	Express/Savana	Body	Theft Deterrent Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
G	2009	Express Access/Savana Pro	Body	Body Control Module																																								
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2009	Express Access/Savana Pro	Body	Radio																																								
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																								
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
G	2010	Express/Savana	Body	Body Control Module																																								
G	2010	Express/Savana	Body	Instrument Panel Cluster																																								
G	2010	Express/Savana	Body	Passenger Presence System																																								
G	2010	Express/Savana	Body	Radio																																								
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																								
G	2010	Express/Savana	Body	Rollover Sensor																																								
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2010	Express/Savana	Body	Theft Deterrent Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
G	2010	Express Access/Savana Pro	Body	Body Control Module																																								
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2010	Express Access/Savana Pro	Body	Radio																																								
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																								
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
G	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
G	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
G	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
G	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
G	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
G	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
G	2011	Express/Savana	Body	Body Control Module																																								
G	2011	Express/Savana	Body	Digital Radio Receiver																																								
G	2011	Express/Savana	Body	Instrument Panel Cluster																																								
G	2011	Express/Savana	Body	Passenger Presence System																																								
G	2011	Express/Savana	Body	Radio																																								
G	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																								
G	2011	Express/Savana	Body	Rollover Sensor																																								
G	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2011	Express/Savana	Body	Theft Deterrent Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
G	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
G	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
G	2011	Express Access/Savana Pro	Body	Body Control Module																																								
G	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																								
G	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2011	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2011	Express Access/Savana Pro	Body	Radio																																								
G	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2011	Express Access/Savana Pro	Body	Rollover Sensor																																								
G	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
G	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
G	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
G	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
G	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
G	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
G	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
G	2012	Express/Savana	Body	Body Control Module																																								
G	2012	Express/Savana	Body	Digital Radio Receiver																																								
G	2012	Express/Savana	Body	Instrument Panel Cluster																																								
G	2012	Express/Savana	Body	Passenger Presence System																																								
G	2012	Express/Savana	Body	Radio																																								
G	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																								
G	2012	Express/Savana	Body	Rollover Sensor																																								
G	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2012	Express/Savana	Body	Theft Deterrent Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
G	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
G	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
G	2012	Express Access/Savana Pro	Body	Body Control Module																																								
G	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																								
G	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2012	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2012	Express Access/Savana Pro	Body	Radio																																								
G	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2012	Express Access/Savana Pro	Body	Rollover Sensor																																								
G	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
G	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
G	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
G	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
G	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
G	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
G	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
G	2013	Express/Savana	Body	Body Control Module																																								
G	2013	Express/Savana	Body	Digital Radio Receiver																																								
G	2013	Express/Savana	Body	Instrument Panel Cluster																																								
G	2013	Express/Savana	Body	Navigation Radio																																								
G	2013	Express/Savana	Body	Park Assist Module																																								
G	2013	Express/Savana	Body	Passenger Presence System																																								
G	2013	Express/Savana	Body	Radio																																								
G	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																								
G	2013	Express/Savana	Body	Rollover Sensor																																								
G	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2013	Express/Savana	Body	Theft Deterrent Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
G	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
G	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
G	2013	Express Access/Savana Pro	Body	Body Control Module																																								
G	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																								
G	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2013	Express Access/Savana Pro	Body	Navigation Radio																																								
G	2013	Express Access/Savana Pro	Body	Park Assist Module																																								
G	2013	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2013	Express Access/Savana Pro	Body	Radio																																								
G	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2013	Express Access/Savana Pro	Body	Rollover Sensor																																								
G	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
G	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																								
G	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																								
G	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																								
G	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																								
G	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																								
G	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																								
G	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																								
G	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																								
G	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
G	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
G	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
G	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																								
G	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
G	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
G	2014	Express	Chassis	Electronic Brake Control Module																																								
G	2014	Express	Body	Body Control Module																																								
G	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
G	2014	Express	Body	Passenger Presence Module																																								
G	2014	Express	Body	Rollover Sensor Module																																								
G	2014	Express	Body	Instrument Cluster																																								
G	2014	Express	Body	Chime Alarm Control Module																																								
G	2014	Express	Body	Base Radio																																								
G	2014	Express	Body	Navigation Radio																																								
G	2014	Express	Body	Uplevel Radio																																								
G	2014	Express	Body	Digital Radio Receiver Control Module																																								
G	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																								
G	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																								
G	2014	Express	Body	Auxiliary Heater Control Module																																								
G	2014	Express	Body	Remote Control Door Lock Receiver																																								
G	2014	Express	Body	Parking Assist Control Module																																								
G	2014	Express	Body	Theft Deterrent Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																								
G	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																								
G	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																								
G	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																								
G	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																								
G	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																								
G	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																								
G	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																								
G	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
G	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
G	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
G	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								
G	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
G	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
G	2014	Savana	Chassis	Electronic Brake Control Module																																								
G	2014	Savana	Body	Body Control Module																																								
G	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
G	2014	Savana	Body	Passenger Presence Module																																								
G	2014	Savana	Body	Rollover Sensor Module																																								
G	2014	Savana	Body	Instrument Cluster																																								
G	2014	Savana	Body	Chime Alarm Control Module																																								
G	2014	Savana	Body	Base Radio																																								
G	2014	Savana	Body	Navigation Radio																																								
G	2014	Savana	Body	Uplevel Radio																																								
G	2014	Savana	Body	Digital Radio Receiver Control Module																																								
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																								
G	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																								
G	2014	Savana	Body	Auxiliary Heater Control Module																																								
G	2014	Savana	Body	Remote Control Door Lock Receiver																																								
G	2014	Savana	Body	Parking Assist Control Module																																								
G	2014	Savana	Body	Theft Deterrent Module																																								
G	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																								
G	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																								
G	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																								
G	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
G	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
G	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
G	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																								
G	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
G	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
G	2015	Express	Chassis	Electronic Brake Control Module																																								
G	2015	Express	Body	Body Control Module																																								
G	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
G	2015	Express	Body	Rollover Sensor Module																																								
G	2015	Express	Body	Instrument Cluster																																								
G	2015	Express	Body	Digital Radio Receiver Control Module																																								
G	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																								
G	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																								
G	2015	Express	Body	Auxiliary Heater Control Module																																								
G	2015	Express	Body	Remote Control Door Lock Receiver																																								
G	2015	Express	Body	Parking Assist Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2015	Express	Body	Theft Deterrent Module																																								
G	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																								
G	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																								
G	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																								
G	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
G	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
G	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
G	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								
G	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
G	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
G	2015	Savana	Chassis	Electronic Brake Control Module																																								
G	2015	Savana	Body	Body Control Module																																								
G	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
G	2015	Savana	Body	Rollover Sensor Module																																								
G	2015	Savana	Body	Instrument Cluster																																								
G	2015	Savana	Body	Digital Radio Receiver Control Module																																								
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																								
G	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																								
G	2015	Savana	Body	Auxiliary Heater Control Module																																								
G	2015	Savana	Body	Remote Control Door Lock Receiver																																								
G	2015	Savana	Body	Parking Assist Control Module																																								
G	2015	Savana	Body	Theft Deterrent Module																																								
G	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																								
G	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																								
G	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																								
G	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
G	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
G	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
G	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																								
G	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
G	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
G	2016	Express	Chassis	Electronic Brake Control Module																																								
G	2016	Express	Body	Body Control Module																																								
G	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
G	2016	Express	Body	Instrument Cluster																																								
G	2016	Express	Body	Chime Alarm Control Module																																								
G	2016	Express	Body	Base Radio																																								
G	2016	Express	Body	Navigation Radio																																								
G	2016	Express	Body	Uplevel Radio																																								
G	2016	Express	Body	Digital Radio Receiver Control Module																																								
G	2016	Express	Body	Telematics Communication Interface Control Module																																								
G	2016	Express	Body	Auxiliary Heater Control Module																																								
G	2016	Express	Body	Remote Control Door Lock Receiver																																								
G	2016	Express	Body	Parking Assist Control Module																																								
G	2016	Express	Body	Theft Deterrent Module																																								
G	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																								
G	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																								
G	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																								
G	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
G	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
G	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								
G	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
G	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
G	2016	Savana	Chassis	Electronic Brake Control Module																																								
G	2016	Savana	Body	Body Control Module																																								
G	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
G	2016	Savana	Body	Instrument Cluster																																								
G	2016	Savana	Body	Chime Alarm Control Module																																								
G	2016	Savana	Body	Digital Radio Receiver Control Module																																								
G	2016	Savana	Body	Telematics Communication Interface Control Module																																								
G	2016	Savana	Body	Auxiliary Heater Control Module																																								
G	2016	Savana	Body	Remote Control Door Lock Receiver																																								
G	2016	Savana	Body	Parking Assist Control Module																																								
G	2016	Savana	Body	Theft Deterrent Module																																								
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																								
H	2004	Express/Savana	Chassis	VSES																																								
H	2004	Express/Savana	Body	Body Control Module																																								
H	2004	Express/Savana	Body	Instrument Panel Cluster																																								
H	2004	Express/Savana	Body	Multifunction Alarm Module																																								
H	2004	Express/Savana	Body	OnStar																																								
H	2004	Express/Savana	Body	Base Radio																																								
H	2004	Express/Savana	Body	Uplevel Radio																																								
H	2004	Express/Savana	Body	Remote Function Actuation																																								
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																								
H	2004	Express Access/Savana Pro	Chassis	VSES																																								
H	2004	Express Access/Savana Pro	Body	Body Control Module																																								
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
H	2004	Express Access/Savana Pro	Body	OnStar																																								
H	2004	Express Access/Savana Pro	Body	Base Radio																																								
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																								
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																								
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																								
H	2005	Express/Savana	Chassis	VSES																																								
H	2005	Express/Savana	Body	Body Control Module																																								
H	2005	Express/Savana	Body	Instrument Panel Cluster																																								
H	2005	Express/Savana	Body	Multifunction Alarm Module																																								
H	2005	Express/Savana	Body	Base Radio																																								
H	2005	Express/Savana	Body	Uplevel Radio																																								
H	2005	Express/Savana	Body	Remote Function Actuation																																								
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																								
H	2005	Express Access/Savana Pro	Chassis	VSES																																								
H	2005	Express Access/Savana Pro	Body	Body Control Module																																								
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
H	2005	Express Access/Savana Pro	Body	Base Radio																																								
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																								
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																								
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																								
H	2006	Express/Savana	Chassis	VSES																																								
H	2006	Express/Savana	Body	Body Control Module																																								
H	2006	Express/Savana	Body	Instrument Panel Cluster																																								
H	2006	Express/Savana	Body	Multifunction Alarm Module																																								
H	2006	Express/Savana	Body	Passenger Presence System																																								
H	2006	Express/Savana	Body	Base Radio																																								
H	2006	Express/Savana	Body	Uplevel Radio																																								
H	2006	Express/Savana	Body	Remote Function Actuation																																								
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																								
H	2006	Express Access/Savana Pro	Chassis	VSES																																								
H	2006	Express Access/Savana Pro	Body	Body Control Module																																								
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2006	Express Access/Savana Pro	Body	Base Radio																																								
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																								
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																								
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																								
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
H	2007	Express/Savana	Body	Body Control Module																																								
H	2007	Express/Savana	Body	Instrument Panel Cluster																																								
H	2007	Express/Savana	Body	Multifunction Alarm Module																																								
H	2007	Express/Savana	Body	Passenger Presence System																																								
H	2007	Express/Savana	Body	Base Radio																																								
H	2007	Express/Savana	Body	Uplevel Radio																																								
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																								
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																								
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
H	2007	Express Access/Savana Pro	Body	Body Control Module																																								
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2007	Express Access/Savana Pro	Body	Base Radio																																								
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																								
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																								
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
H	2008	Express/Savana	Body	Body Control Module																																								
H	2008	Express/Savana	Body	Instrument Panel Cluster																																								
H	2008	Express/Savana	Body	Passenger Presence System																																								
H	2008	Express/Savana	Body	Radio																																								
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																								
H	2008	Express/Savana	Body	Rollover Sensor																																								
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2008	Express/Savana	Body	Theft Deterrent Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
H	2008	Express Access/Savana Pro	Body	Body Control Module																																								
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2008	Express Access/Savana Pro	Body	Radio																																								
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																								
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
H	2009	Express/Savana	Body	Body Control Module																																								
H	2009	Express/Savana	Body	Instrument Panel Cluster																																								
H	2009	Express/Savana	Body	Passenger Presence System																																								
H	2009	Express/Savana	Body	Radio																																								
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																								
H	2009	Express/Savana	Body	Rollover Sensor																																								
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2009	Express/Savana	Body	Theft Deterrent Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
H	2009	Express Access/Savana Pro	Body	Body Control Module																																								
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2009	Express Access/Savana Pro	Body	Radio																																								
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
H	2010	Express/Savana	Body	Body Control Module																																								
H	2010	Express/Savana	Body	Instrument Panel Cluster																																								
H	2010	Express/Savana	Body	Passenger Presence System																																								
H	2010	Express/Savana	Body	Radio																																								
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																								
H	2010	Express/Savana	Body	Rollover Sensor																																								
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2010	Express/Savana	Body	Theft Deterrent Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
H	2010	Express Access/Savana Pro	Body	Body Control Module																																								
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2010	Express Access/Savana Pro	Body	Radio																																								
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																								
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
H	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
H	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
H	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
H	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
H	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
H	2011	Express/Savana	Body	Body Control Module																																								
H	2011	Express/Savana	Body	Digital Radio Receiver																																								
H	2011	Express/Savana	Body	Instrument Panel Cluster																																								
H	2011	Express/Savana	Body	Passenger Presence System																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2011	Express/Savana	Body	Radio																																								
H	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																								
H	2011	Express/Savana	Body	Rollover Sensor																																								
H	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2011	Express/Savana	Body	Theft Deterrent Module																																								
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
H	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
H	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
H	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
H	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
H	2011	Express Access/Savana Pro	Body	Body Control Module																																								
H	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																								
H	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2011	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2011	Express Access/Savana Pro	Body	Radio																																								
H	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
H	2011	Express Access/Savana Pro	Body	Rollover Sensor																																								
H	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
H	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
H	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
H	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
H	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
H	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
H	2012	Express/Savana	Body	Body Control Module																																								
H	2012	Express/Savana	Body	Digital Radio Receiver																																								
H	2012	Express/Savana	Body	Instrument Panel Cluster																																								
H	2012	Express/Savana	Body	Passenger Presence System																																								
H	2012	Express/Savana	Body	Radio																																								
H	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																								
H	2012	Express/Savana	Body	Rollover Sensor																																								
H	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2012	Express/Savana	Body	Theft Deterrent Module																																								
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
H	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
H	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
H	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
H	2012	Express Access/Savana Pro	Body	Body Control Module																																								
H	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																								
H	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2012	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2012	Express Access/Savana Pro	Body	Radio																																								
H	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
H	2012	Express Access/Savana Pro	Body	Rollover Sensor																																								
H	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
H	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
H	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
H	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
H	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
H	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
H	2013	Express/Savana	Body	Body Control Module																																								
H	2013	Express/Savana	Body	Digital Radio Receiver																																								
H	2013	Express/Savana	Body	Instrument Panel Cluster																																								
H	2013	Express/Savana	Body	Navigation Radio																																								
H	2013	Express/Savana	Body	Park Assist Module																																								
H	2013	Express/Savana	Body	Passenger Presence System																																								
H	2013	Express/Savana	Body	Radio																																								
H	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																								
H	2013	Express/Savana	Body	Rollover Sensor																																								
H	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2013	Express/Savana	Body	Theft Deterrent Module																																								
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
H	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
H	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
H	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
H	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
H	2013	Express Access/Savana Pro	Body	Body Control Module																																								
H	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																								
H	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2013	Express Access/Savana Pro	Body	Navigation Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2013	Express Access/Savana Pro	Body	Park Assist Module																																								
H	2013	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2013	Express Access/Savana Pro	Body	Radio																																								
H	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
H	2013	Express Access/Savana Pro	Body	Rollover Sensor																																								
H	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
H	2014	Express	Powertrain	(X) 4.3L LU3 Engine Control Module																																								
H	2014	Express	Powertrain	(X) 4.3L LU3 Transmission Control Module																																								
H	2014	Express	Powertrain	(A) 4.8L L20 Engine Control Module																																								
H	2014	Express	Powertrain	(A) 4.8L L20 Transmission Control Module																																								
H	2014	Express	Powertrain	(4) 5.3L LMF Engine Control Module																																								
H	2014	Express	Powertrain	(4) 5.3L LMF Chassis Control Module																																								
H	2014	Express	Powertrain	(4) 5.3L LMF Transmission Control Module																																								
H	2014	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																								
H	2014	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
H	2014	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
H	2014	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
H	2014	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																								
H	2014	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
H	2014	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
H	2014	Express	Chassis	Electronic Brake Control Module																																								
H	2014	Express	Body	Body Control Module																																								
H	2014	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
H	2014	Express	Body	Passenger Presence Module																																								
H	2014	Express	Body	Rollover Sensor Module																																								
H	2014	Express	Body	Instrument Cluster																																								
H	2014	Express	Body	Chime Alarm Control Module																																								
H	2014	Express	Body	Base Radio																																								
H	2014	Express	Body	Navigation Radio																																								
H	2014	Express	Body	Uplevel Radio																																								
H	2014	Express	Body	Digital Radio Receiver Control Module																																								
H	2014	Express	Body	Telematics Communication Interface Control Module Version 9																																								
H	2014	Express	Body	Telematics Communication Interface Control Module Version 10																																								
H	2014	Express	Body	Auxiliary Heater Control Module																																								
H	2014	Express	Body	Remote Control Door Lock Receiver																																								
H	2014	Express	Body	Parking Assist Control Module																																								
H	2014	Express	Body	Theft Deterrent Module																																								
H	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																								
H	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																								
H	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																								
H	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																								
H	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																								
H	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																								
H	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																								
H	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																								
H	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
H	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
H	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
H	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								
H	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
H	2014	Savana	Chassis	Electronic Brake Control Module																																								
H	2014	Savana	Body	Body Control Module																																								
H	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
H	2014	Savana	Body	Passenger Presence Module																																								
H	2014	Savana	Body	Rollover Sensor Module																																								
H	2014	Savana	Body	Instrument Cluster																																								
H	2014	Savana	Body	Chime Alarm Control Module																																								
H	2014	Savana	Body	Base Radio																																								
H	2014	Savana	Body	Navigation Radio																																								
H	2014	Savana	Body	Uplevel Radio																																								
H	2014	Savana	Body	Digital Radio Receiver Control Module																																								
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																								
H	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																								
H	2014	Savana	Body	Auxiliary Heater Control Module																																								
H	2014	Savana	Body	Remote Control Door Lock Receiver																																								
H	2014	Savana	Body	Parking Assist Control Module																																								
H	2014	Savana	Body	Theft Deterrent Module																																								
H	2015	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																								
H	2015	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																								
H	2015	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																								
H	2015	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
H	2015	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
H	2015	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
H	2015	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																								
H	2015	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
H	2015	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
H	2015	Express	Chassis	Electronic Brake Control Module																																								
H	2015	Express	Body	Body Control Module																																								
H	2015	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
H	2015	Express	Body	Rollover Sensor Module																																								
H	2015	Express	Body	Instrument Cluster																																								
H	2015	Express	Body	Digital Radio Receiver Control Module																																								
H	2015	Express	Body	Telematics Communication Interface Control Module Version 9																																								
H	2015	Express	Body	Telematics Communication Interface Control Module Version 10																																								
H	2015	Express	Body	Auxiliary Heater Control Module																																								
H	2015	Express	Body	Remote Control Door Lock Receiver																																								
H	2015	Express	Body	Parking Assist Control Module																																								
H	2015	Express	Body	Theft Deterrent Module																																								
H	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																								
H	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																								
H	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																								
H	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
H	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
H	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
H	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								
H	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
H	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
H	2015	Savana	Chassis	Electronic Brake Control Module																																								
H	2015	Savana	Body	Body Control Module																																								
H	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2015	Savana	Body	Rollover Sensor Module																																								
H	2015	Savana	Body	Instrument Cluster																																								
H	2015	Savana	Body	Digital Radio Receiver Control Module																																								
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																								
H	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																								
H	2015	Savana	Body	Auxiliary Heater Control Module																																								
H	2015	Savana	Body	Remote Control Door Lock Receiver																																								
H	2015	Savana	Body	Parking Assist Control Module																																								
H	2015	Savana	Body	Theft Deterrent Module																																								
H	2016	Express	Powertrain	(F) 4.8L L20 Engine Control Module																																								
H	2016	Express	Powertrain	(F) 4.8L L20 Transmission Control Module																																								
H	2016	Express	Powertrain	(G) 6.0L L96 Engine Control Module																																								
H	2016	Express	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
H	2016	Express	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
H	2016	Express	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
H	2016	Express	Powertrain	(L) 6.6L LGH Engine Control Module																																								
H	2016	Express	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
H	2016	Express	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
H	2016	Express	Chassis	Electronic Brake Control Module																																								
H	2016	Express	Body	Body Control Module																																								
H	2016	Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
H	2016	Express	Body	Instrument Cluster																																								
H	2016	Express	Body	Chime Alarm Control Module																																								
H	2016	Express	Body	Base Radio																																								
H	2016	Express	Body	Navigation Radio																																								
H	2016	Express	Body	Uplevel Radio																																								
H	2016	Express	Body	Digital Radio Receiver Control Module																																								
H	2016	Express	Body	Telematics Communication Interface Control Module																																								
H	2016	Express	Body	Auxiliary Heater Control Module																																								
H	2016	Express	Body	Remote Control Door Lock Receiver																																								
H	2016	Express	Body	Parking Assist Control Module																																								
H	2016	Express	Body	Theft Deterrent Module																																								
H	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																								
H	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																								
H	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																								
H	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
H	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
H	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
H	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								
H	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
H	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
H	2016	Savana	Chassis	Electronic Brake Control Module																																								
H	2016	Savana	Body	Body Control Module																																								
H	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
H	2016	Savana	Body	Instrument Cluster																																								
H	2016	Savana	Body	Chime Alarm Control Module																																								
H	2016	Savana	Body	Digital Radio Receiver Control Module																																								
H	2016	Savana	Body	Telematics Communication Interface Control Module																																								
H	2016	Savana	Body	Auxiliary Heater Control Module																																								
H	2016	Savana	Body	Remote Control Door Lock Receiver																																								
H	2016	Savana	Body	Parking Assist Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2016	Savana	Body	Theft Deterrent Module																																								
J	2004	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																								
J	2004	ALL	Powertrain	(4)2.5L V6 LE8 Engine Control Module																																								
J	2004	ALL	Chassis	Electronic Brake Control Module																																								
J	2005	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																								
J	2007	ALL	Powertrain	(C)2.0L L4 L34 Engine Control Module																																								
J	2007	ALL	Chassis	Electronic Brake Control Module																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																								
J	2013	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																								
J	2013	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																								
J	2013	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																								
J	2013	Tracker	Powertrain	1.7L LUD Transmission Control Module																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																								
J	2013	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																								
J	2013	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Automatic Transmission																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																								
J	2013	Tracker	Powertrain	(T) 1.8L LFH Transmission Control Module																																								
J	2013	Tracker	Powertrain	Rear Differential Clutch Control Module																																								
J	2013	Tracker	Chassis	Electronic Brake Control Module																																								
J	2013	Tracker	Chassis	Multi-Axis Acceleration Sensor Module																																								
J	2013	Tracker	Chassis	Power Steering Control Module																																								
J	2013	Tracker	Chassis	Steering Wheel Angle Sensor Module																																								
J	2013	Tracker	Body	Body Control Module																																								
J	2013	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
J	2013	Tracker	Body	Passenger Presence Module																																								
J	2013	Tracker	Body	Instrument Cluster																																								
J	2013	Tracker	Body	Radio																																								
J	2013	Tracker	Body	Telematics Communication Interface Control Module																																								
J	2013	Tracker	Body	HVAC Control Module Heater Only (C41)																																								
J	2013	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																								
J	2013	Tracker	Body	HVAC Control Module Single Zone (C60)																																								
J	2013	Tracker	Body	Front Seat Heating Control Module																																								
J	2013	Tracker	Body	Parking Assist Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
J	2013	Tracker	Body	Frontview Camera Module																																								
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																								
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																								
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																								
J	2013	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																								
J	2013	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																								
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																								
J	2013	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																								
J	2013	Trax	Powertrain	(B) 1.4L LUV Fuel Pump Control Module																																								
J	2013	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																								
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																								
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																								
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																								
J	2013	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																								
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																								
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																								
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																								
J	2013	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																								
J	2013	Trax	Powertrain	1.7L LUD Transmission Control Module																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																								
J	2013	Trax	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																								
J	2013	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
J	2013	Trax	Powertrain	Rear Differential Clutch Control Module																																								
J	2013	Trax	Chassis	Electronic Brake Control Module																																								
J	2013	Trax	Chassis	Multi-Axis Acceleration Sensor Module																																								
J	2013	Trax	Chassis	Power Steering Control Module																																								
J	2013	Trax	Chassis	Steering Wheel Angle Sensor Module																																								
J	2013	Trax	Body	Body Control Module																																								
J	2013	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
J	2013	Trax	Body	Passenger Presence Module																																								
J	2013	Trax	Body	Instrument Cluster																																								
J	2013	Trax	Body	Radio																																								
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 9																																								
J	2013	Trax	Body	Telematics Communication Interface Control Module Version 10																																								
J	2013	Trax	Body	HVAC Control Module Heater Only (C41)																																								
J	2013	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																								
J	2013	Trax	Body	HVAC Control Module Single Zone (C60)																																								
J	2013	Trax	Body	Front Seat Heating Control Module																																								
J	2013	Trax	Body	Parking Assist Control Module																																								
J	2013	Trax	Body	Frontview Camera Module																																								
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																								
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																								
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (M4P)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission (MFH)																																								
J	2014	Tracker	Powertrain	(8) 1.4L LUJ Transmission Control Module																																								
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (M4P)																																								
J	2014	Tracker	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission (MFH)																																								
J	2014	Tracker	Powertrain	(B) 1.4L LUV Chassis Control Module																																								
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																								
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																								
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																								
J	2014	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																								
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																								
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																								
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																								
J	2014	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																								
J	2014	Tracker	Powertrain	1.7L LUD Transmission Control Module																																								
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																								
J	2014	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																								
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																								
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																								
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																								
J	2014	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																								
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																								
J	2014	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																								
J	2014	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																								
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																								
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																								
J	2014	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																								
J	2014	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																								
J	2014	Tracker	Powertrain	Rear Differential Clutch Control Module																																								
J	2014	Tracker	Chassis	Electronic Brake Control Module																																								
J	2014	Tracker	Chassis	Power Steering Control Module																																								
J	2014	Tracker	Chassis	Steering Wheel Angle Sensor Module																																								
J	2014	Tracker	Body	Body Control Module																																								
J	2014	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
J	2014	Tracker	Body	Passenger Presence Module																																								
J	2014	Tracker	Body	Instrument Cluster																																								
J	2014	Tracker	Body	Radio																																								
J	2014	Tracker	Body	Telematics Communication Interface Control Module																																								
J	2014	Tracker	Body	HVAC Control Module Heater Only (C41)																																								
J	2014	Tracker	Body	HVAC Control Module Air Conditioning Only (C7B)																																								
J	2014	Tracker	Body	HVAC Control Module Single Zone (C60)																																								
J	2014	Tracker	Body	Front Seat Heating Control Module																																								
J	2014	Tracker	Body	Parking Assist Control Module																																								
J	2014	Tracker	Body	Frontview Camera Module																																								
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																								
J	2014	Trax	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																								
J	2014	Trax	Powertrain	(8) 1.4L LUJ Transmission Control Module																																								
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								
J	2014	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
J	2014	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																								
J	2014	Trax	Powertrain	(B) 1.4L LUV Chassis Control Module																																								
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																								
J	2014	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																								
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																								
J	2014	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																								
J	2014	Trax	Powertrain	1.7L LUD Transmission Control Module																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																								
J	2014	Trax	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																								
J	2014	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
J	2014	Trax	Powertrain	Fuel Injector Control Module																																								
J	2014	Trax	Powertrain	Rear Differential Clutch Control Module																																								
J	2014	Trax	Chassis	Electronic Brake Control Module																																								
J	2014	Trax	Chassis	Power Steering Control Module																																								
J	2014	Trax	Chassis	Steering Wheel Angle Sensor Module																																								
J	2014	Trax	Body	Body Control Module																																								
J	2014	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
J	2014	Trax	Body	Passenger Presence Module																																								
J	2014	Trax	Body	Instrument Cluster																																								
J	2014	Trax	Body	Radio																																								
J	2014	Trax	Body	Telematics Communication Interface Control Module Version 10																																								
J	2014	Trax	Body	HVAC Control Module Heater Only (C41)																																								
J	2014	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																								
J	2014	Trax	Body	HVAC Control Module Single Zone (C60)																																								
J	2014	Trax	Body	Front Seat Heating Control Module																																								
J	2014	Trax	Body	Parking Assist Control Module																																								
J	2014	Trax	Body	Frontview Camera Module																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (M4P)																																								
J	2015	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission (MFH)																																								
J	2015	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (M4P)																																								
J	2015	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission (MFH)																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (M4P)																																								
J	2015	Tracker	Powertrain	1.6L LVL Engine Control Module Manual Transmission (MFH)																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (M4P)																																								
J	2015	Tracker	Powertrain	1.7L LUD Engine Control Module Manual Transmission (MFH)																																								
J	2015	Tracker	Powertrain	1.7L LUD Transmission Control Module																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) 2WD Transfer																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission (M4P) AWD Transfer																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) 2WD Transfer																																								
J	2015	Tracker	Powertrain	1.8L 2HO Engine Control Transmission (MFH) AWD Transfer																																								
J	2015	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (M4P)																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission (MFH)																																								
J	2015	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																								
J	2015	Tracker	Powertrain	Rear Differential Clutch Control Module																																								
J	2015	Tracker	Chassis	Electronic Brake Control Module																																								
J	2015	Tracker	Chassis	Power Steering Control Module																																								
J	2015	Tracker	Chassis	Steering Wheel Angle Sensor Module																																								
J	2015	Tracker	Body	Body Control Module																																								
J	2015	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
J	2015	Tracker	Body	Instrument Cluster																																								
J	2015	Tracker	Body	Telematics Communication Interface Control Module																																								
J	2015	Tracker	Body	HVAC Control Module Heater Only (C41)																																								
J	2015	Tracker	Body	HVAC Control Module Single Zone (C60)																																								
J	2015	Tracker	Body	Front Seat Heating Control Module																																								
J	2015	Tracker	Body	Parking Assist Control Module																																								
J	2015	Tracker	Body	Frontview Camera Module																																								
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
J	2015	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
J	2015	Trax	Powertrain	1.4L LUJ Transmission Control Module																																								
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								
J	2015	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								
J	2015	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																								
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																								
J	2015	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																								
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																								
J	2015	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																								
J	2015	Trax	Powertrain	1.6L LVL Transmission Control Module																																								
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Automatic Transmission																																								
J	2015	Trax	Powertrain	1.7L LUD Engine Control Module Manual Transmission																																								
J	2015	Trax	Powertrain	1.7L LUD Transmission Control Module																																								
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																								
J	2015	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																								
J	2015	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
J	2015	Trax	Powertrain	Fuel Injector Control Module																																								
J	2015	Trax	Powertrain	Chassis Control Module																																								
J	2015	Trax	Powertrain	Rear Differential Clutch Control Module																																								
J	2015	Trax	Chassis	Electronic Brake Control Module																																								
J	2015	Trax	Chassis	Power Steering Control Module																																								
J	2015	Trax	Chassis	Steering Wheel Angle Sensor Module																																								
J	2015	Trax	Body	Body Control Module																																								
J	2015	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
J	2015	Trax	Body	Passenger Presence Module																																								
J	2015	Trax	Body	Instrument Cluster																																								
J	2015	Trax	Body	Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																								
J	2015	Trax	Body	Telematics Communication Interface Control Module Version 10																																								
J	2015	Trax	Body	HVAC Control Module Heater Only (C41)																																								
J	2015	Trax	Body	HVAC Control Module Air Conditioning Only (C7B)																																								
J	2015	Trax	Body	HVAC Control Module Single Zone (C60)																																								
J	2015	Trax	Body	Seat Memory Control Module																																								
J	2015	Trax	Body	Front Seat Heating Control Module																																								
J	2015	Trax	Body	Right Side Object Detection Control Module																																								
J	2015	Trax	Body	Left Side Object Detection Control Module																																								
J	2015	Trax	Body	Parking Assist Control Module																																								
J	2015	Trax	Body	Frontview Camera Module																																								
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
J	2016	Tracker	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
J	2016	Tracker	Powertrain	1.4L LUJ Transmission Control Module																																								
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																								
J	2016	Tracker	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																								
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission 2WD Transfer																																								
J	2016	Tracker	Powertrain	1.8L 2HO Engine Auto Transmission AWD Transfer																																								
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission 2WD Transfer																																								
J	2016	Tracker	Powertrain	1.8L 2HO Engine Manual Transmission AWD Transfer																																								
J	2016	Tracker	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Automatic Transmission																																								
J	2016	Tracker	Powertrain	(W) 1.8L LFH Engine Control Module Manual Transmission																																								
J	2016	Tracker	Powertrain	(W) 1.8L LFH Transmission Control Module																																								
J	2016	Tracker	Powertrain	Fuel Injector Control Module																																								
J	2016	Tracker	Chassis	Electronic Brake Control Module																																								
J	2016	Tracker	Chassis	Power Steering Control Module																																								
J	2016	Tracker	Chassis	Steering Wheel Angle Sensor Module																																								
J	2016	Tracker	Body	Body Control Module																																								
J	2016	Tracker	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
J	2016	Tracker	Body	Instrument Cluster																																								
J	2016	Tracker	Body	Trailer Interface Control Module																																								
J	2016	Tracker	Body	Radio																																								
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 9.7																																								
J	2016	Tracker	Body	Telematics Communication Interface Control Module Version 10																																								
J	2016	Tracker	Body	HVAC Control Module Heater Only (C41)																																								
J	2016	Tracker	Body	HVAC Control Module Single Zone (C60)																																								
J	2016	Tracker	Body	Front Seat Heating Control Module																																								
J	2016	Tracker	Body	Parking Assist Control Module																																								
J	2016	Tracker	Body	Frontview Camera Module																																								
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Automatic Transmission																																								
J	2016	Trax	Powertrain	(M) 1.4L LE2 Engine Control Module Manual Transmission																																								
J	2016	Trax	Powertrain	(M) 1.4L LE2 Transmission Control Module																																								
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Automatic Transmission																																								
J	2016	Trax	Powertrain	1.4L LFF Engine Control Module Manual Transmission																																								
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
J	2016	Trax	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
J	2016	Trax	Powertrain	1.4L LUJ Transmission Control Module																																								
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Automatic Transmission																																								
J	2016	Trax	Powertrain	(B) 1.4L LUV Engine Control Module Manual Transmission																																								
J	2016	Trax	Powertrain	(B) 1.4L LUV Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Automatic Transmission																																								
J	2016	Trax	Powertrain	1.6L LDE Engine Control Module Manual Transmission																																								
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																								
J	2016	Trax	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																								
J	2016	Trax	Powertrain	1.6L LVL Transmission Control Module																																								
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Automatic Transmission																																								
J	2016	Trax	Powertrain	1.8L 2HO Engine Control Module Manual Transmission																																								
J	2016	Trax	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
J	2016	Trax	Powertrain	Fuel Injector Control Module																																								
J	2016	Trax	Powertrain	Chassis Control Module																																								
J	2016	Trax	Chassis	Electronic Brake Control Module																																								
J	2016	Trax	Chassis	Power Steering Control Module																																								
J	2016	Trax	Chassis	Steering Wheel Angle Sensor Module																																								
J	2016	Trax	Body	Body Control Module																																								
J	2016	Trax	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
J	2016	Trax	Body	Passenger Presence Module																																								
J	2016	Trax	Body	Instrument Cluster																																								
J	2016	Trax	Body	Trailer Interface Control Module																																								
J	2016	Trax	Body	Radio																																								
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 9.7																																								
J	2016	Trax	Body	Telematics Communication Interface Control Module Version 10																																								
J	2016	Trax	Body	HVAC Control Module Heater Only (C41)																																								
J	2016	Trax	Body	HVAC Control Module Single Zone (C60)																																								
J	2016	Trax	Body	Seat Memory Control Module																																								
J	2016	Trax	Body	Front Seat Heating Control Module																																								
J	2016	Trax	Body	Right Side Object Detection Control Module																																								
J	2016	Trax	Body	Left Side Object Detection Control Module																																								
J	2016	Trax	Body	Parking Assist Control Module																																								
J	2016	Trax	Body	Frontview Camera Module																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																								
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																								
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																								
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																								
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																								
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																								
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																								
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																								
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																								
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
K	2004	ALL	Chassis	ABS Over 8600 GVW																																								
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																								
K	2004	ALL	Chassis	ESC																																								
K	2004	ALL	Chassis	Rear Wheel Steering																																								
K	2004	ALL	Chassis	Tire Pressure Monitor																																								
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																								
K	2004	ALL	Chassis	VSES																																								
K	2004	ALL	Body	Amplifier (Bose)																																								
K	2004	ALL	Body	Body Control Module																																								
K	2004	ALL	Body	CD Changer																																								
K	2004	ALL	Body	Chime																																								
K	2004	ALL	Body	Driver Door Module																																								
K	2004	ALL	Body	Driver Seat Module																																								
K	2004	ALL	Body	Heating and Air Conditioning Auto																																								
K	2004	ALL	Body	Heating and Air Conditioning Manual																																								
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																								
K	2004	ALL	Body	Instrument Panel Cluster																																								
K	2004	ALL	Body	OnStar																																								
K	2004	ALL	Body	Passenger Door Module																																								
K	2004	ALL	Body	Passenger Presence System																																								
K	2004	ALL	Body	Radio Base																																								
K	2004	ALL	Body	Radio Uplevel																																								
K	2004	ALL	Body	Radio Navigation																																								
K	2004	ALL	Body	Rear Aux. Climate Module																																								
K	2004	ALL	Body	Rear HVAC																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2004	ALL	Body	Rear Seat Audio																																								
K	2004	ALL	Body	Rear Seat Entertainment																																								
K	2004	ALL	Body	Supplemental Inflatable Restraint																																								
K	2004	ALL	Body	Vehicle Theft Deterrent																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																								
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																								
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																								
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																								
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																								
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																								
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																								
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																								
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
K	2005	ALL	Chassis	ABS Over 8600 GVW																																								
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																								
K	2005	ALL	Chassis	ESC																																								
K	2005	ALL	Chassis	Rear Wheel Steering																																								
K	2005	ALL	Chassis	Tire Pressure Monitor																																								
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																								
K	2005	ALL	Chassis	VSES																																								
K	2005	ALL	Body	Amplifier (Bose)																																								
K	2005	ALL	Body	Body Control Module																																								
K	2005	ALL	Body	CD Changer																																								
K	2005	ALL	Body	Chime																																								
K	2005	ALL	Body	Disc Player and Video Display																																								
K	2005	ALL	Body	Driver Door Module																																								
K	2005	ALL	Body	Driver Seat Module																																								
K	2005	ALL	Body	Generator Battery Control Module																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																								
K	2005	ALL	Body	Heating and Air Conditioning Manual																																								
K	2005	ALL	Body	Instrument Panel Cluster																																								
K	2005	ALL	Body	Passenger Door Module																																								
K	2005	ALL	Body	Passenger Presence System																																								
K	2005	ALL	Body	Base Radio																																								
K	2005	ALL	Body	Uplevel Radio																																								
K	2005	ALL	Body	Navigation Radio																																								
K	2005	ALL	Body	Rear Aux. Climate Module																																								
K	2005	ALL	Body	Rear HVAC																																								
K	2005	ALL	Body	Rear Seat Audio																																								
K	2005	ALL	Body	Supplemental Inflatable Restraint																																								
K	2005	ALL	Body	Vehicle Comm. Interface Module																																								
K	2005	ALL	Body	Vehicle Theft Deterrent																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																								
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																								
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																								
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																								
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																								
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
K	2006	ALL	Chassis	ABS Over 8600 GVW																																								
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																								
K	2006	ALL	Chassis	ESC																																								
K	2006	ALL	Chassis	Tire Pressure Monitor																																								
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																								
K	2006	ALL	Chassis	VSES																																								
K	2006	ALL	Body	Amplifier (Bose)																																								
K	2006	ALL	Body	Body Control Module																																								
K	2006	ALL	Body	CD Changer																																								
K	2006	ALL	Body	Chime																																								
K	2006	ALL	Body	Disc Player and Video Display																																								
K	2006	ALL	Body	Driver Door Module																																								
K	2006	ALL	Body	Driver Seat Module																																								
K	2006	ALL	Body	Generator Battery Control Module																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																								
K	2006	ALL	Body	Heating and Air Conditioning Manual																																								
K	2006	ALL	Body	Instrument Panel Cluster																																								
K	2006	ALL	Body	Passenger Door Module																																								
K	2006	ALL	Body	Passenger Presence System																																								
K	2006	ALL	Body	Base Radio																																								
K	2006	ALL	Body	Uplevel Radio																																								
K	2006	ALL	Body	Navigation Radio																																								
K	2006	ALL	Body	Rear Aux. Climate Module																																								
K	2006	ALL	Body	Rear HVAC																																								
K	2006	ALL	Body	Rear Seat Audio																																								
K	2006	ALL	Body	Supplemental Inflatable Restraint																																								
K	2006	ALL	Body	Vehicle Theft Deterrent																																								
K	2006	ALL	Body	Vehicle Comm. Interface Module																																								
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2007	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2007	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2007	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2007	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2007	Avalanche	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2007	Avalanche	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2007	Avalanche	Chassis	Electronic Suspension Control																																								
K	2007	Avalanche	Chassis	Trailer Brake Control Module																																								
K	2007	Avalanche	Body	Amplifier (Bose)																																								
K	2007	Avalanche	Body	Assist Step Controller																																								
K	2007	Avalanche	Body	Body Control Module																																								
K	2007	Avalanche	Body	Body Control Module (aux.)																																								
K	2007	Avalanche	Body	Digital Radio Receiver																																								
K	2007	Avalanche	Body	Driver Door Switch																																								
K	2007	Avalanche	Body	HVAC Control Module Auto																																								
K	2007	Avalanche	Body	HVAC Control Module Manual																																								
K	2007	Avalanche	Body	Instrument Panel Cluster																																								
K	2007	Avalanche	Body	Memory Seat Module																																								
K	2007	Avalanche	Body	Park Assist Module																																								
K	2007	Avalanche	Body	Passenger Door Switch																																								
K	2007	Avalanche	Body	Passenger Presence System																																								
K	2007	Avalanche	Body	Radio																																								
K	2007	Avalanche	Body	Rear Heated Seat Module																																								
K	2007	Avalanche	Body	Rear HVAC/RSA																																								
K	2007	Avalanche	Body	Rollover Sensor																																								
K	2007	Avalanche	Body	Supplemental Inflatable Restraint																																								
K	2007	Avalanche	Body	Theft Deterrent Module																																								
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2007	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2007	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2007	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2007	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2007	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2007	Suburban	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2007	Suburban	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2007	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2007	Suburban	Chassis	Electronic Suspension Control																																								
K	2007	Suburban	Chassis	Trailer Brake Control Module																																								
K	2007	Suburban	Body	Amplifier (Bose)																																								
K	2007	Suburban	Body	Assist Step Controller																																								
K	2007	Suburban	Body	Body Control Module																																								
K	2007	Suburban	Body	Body Control Module (aux.)																																								
K	2007	Suburban	Body	Digital Radio Receiver																																								
K	2007	Suburban	Body	Driver Door Switch																																								
K	2007	Suburban	Body	HVAC Control Module Auto																																								
K	2007	Suburban	Body	HVAC Control Module Manual																																								
K	2007	Suburban	Body	Instrument Panel Cluster																																								
K	2007	Suburban	Body	Lift Gate Module																																								
K	2007	Suburban	Body	Memory Seat Module																																								
K	2007	Suburban	Body	Park Assist Module																																								
K	2007	Suburban	Body	Passenger Door Switch																																								
K	2007	Suburban	Body	Passenger Presence System																																								
K	2007	Suburban	Body	Radio																																								
K	2007	Suburban	Body	Rear Heated Seat Module																																								
K	2007	Suburban	Body	Rear HVAC/RSA																																								
K	2007	Suburban	Body	Rollover Sensor																																								
K	2007	Suburban	Body	Supplemental Inflatable Restraint																																								
K	2007	Suburban	Body	Theft Deterrent Module																																								
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
K	2007	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																								
K	2007	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2007	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2007	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2007	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																								
K	2007	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2007	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2007	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																								
K	2007	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
K	2007	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2007	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2007	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2007	Silverado	Chassis	Electronic Suspension Control																																								
K	2007	Silverado	Chassis	Trailer Brake Control Module																																								
K	2007	Silverado	Body	Amplifier (Bose)																																								
K	2007	Silverado	Body	Body Control Module																																								
K	2007	Silverado	Body	Body Control Module (aux.)																																								
K	2007	Silverado	Body	Digital Radio Receiver																																								
K	2007	Silverado	Body	Driver Door Switch																																								
K	2007	Silverado	Body	HVAC Control Module Auto																																								
K	2007	Silverado	Body	HVAC Control Module Manual																																								
K	2007	Silverado	Body	Instrument Panel Cluster																																								
K	2007	Silverado	Body	Memory Seat Module																																								
K	2007	Silverado	Body	Park Assist Module																																								
K	2007	Silverado	Body	Passenger Door Switch																																								
K	2007	Silverado	Body	Passenger Presence System																																								
K	2007	Silverado	Body	Radio																																								
K	2007	Silverado	Body	Rear Heated Seat Module																																								
K	2007	Silverado	Body	Rear HVAC/RSA																																								
K	2007	Silverado	Body	Rollover Sensor																																								
K	2007	Silverado	Body	Supplemental Inflatable Restraint																																								
K	2007	Silverado	Body	Theft Deterrent Module																																								
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																								
K	2007	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2007	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2007	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2007	Tahoe	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2007	Tahoe	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2007	Tahoe	Chassis	Electronic Suspension Control																																								
K	2007	Tahoe	Chassis	Trailer Brake Control Module																																								
K	2007	Tahoe	Body	Amplifier (Bose)																																								
K	2007	Tahoe	Body	Assist Step Controller																																								
K	2007	Tahoe	Body	Body Control Module																																								
K	2007	Tahoe	Body	Body Control Module (aux.)																																								
K	2007	Tahoe	Body	Digital Radio Receiver																																								
K	2007	Tahoe	Body	Driver Door Switch																																								
K	2007	Tahoe	Body	HVAC Control Module Auto																																								
K	2007	Tahoe	Body	HVAC Control Module Manual																																								
K	2007	Tahoe	Body	Instrument Panel Cluster																																								
K	2007	Tahoe	Body	Lift Gate Module																																								
K	2007	Tahoe	Body	Memory Seat Module																																								
K	2007	Tahoe	Body	Park Assist Module																																								
K	2007	Tahoe	Body	Passenger Door Switch																																								
K	2007	Tahoe	Body	Passenger Presence System																																								
K	2007	Tahoe	Body	Radio																																								
K	2007	Tahoe	Body	Rear Heated Seat Module																																								
K	2007	Tahoe	Body	Rear HVAC/RSA																																								
K	2007	Tahoe	Body	Rollover Sensor																																								
K	2007	Tahoe	Body	Supplemental Inflatable Restraint																																								
K	2007	Tahoe	Body	Theft Deterrent Module																																								
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2008	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2008	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2008	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2008	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2008	Avalanche	Chassis	Electronic Brake Control Module																																								
K	2008	Avalanche	Chassis	Electronic Suspension Control																																								
K	2008	Avalanche	Chassis	Trailer Brake Control Module																																								
K	2008	Avalanche	Body	Amplifier (Bose)																																								
K	2008	Avalanche	Body	Assist Step Controller																																								
K	2008	Avalanche	Body	Body Control Module																																								
K	2008	Avalanche	Body	Body Control Module (aux.)																																								
K	2008	Avalanche	Body	Digital Radio Receiver																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2008	Avalanche	Body	Driver Door Switch																																								
K	2008	Avalanche	Body	HVAC Control Module Auto																																								
K	2008	Avalanche	Body	HVAC Control Module Manual																																								
K	2008	Avalanche	Body	Instrument Panel Cluster																																								
K	2008	Avalanche	Body	Memory Seat Module																																								
K	2008	Avalanche	Body	Park Assist Module																																								
K	2008	Avalanche	Body	Passenger Door Switch																																								
K	2008	Avalanche	Body	Passenger Presence System																																								
K	2008	Avalanche	Body	Radio																																								
K	2008	Avalanche	Body	Rear Heated Seat Module																																								
K	2008	Avalanche	Body	Rear HVAC/RSA																																								
K	2008	Avalanche	Body	Rollover Sensor																																								
K	2008	Avalanche	Body	Supplemental Inflatable Restraint																																								
K	2008	Avalanche	Body	Theft Deterrent Module																																								
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2008	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2008	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2008	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2008	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2008	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2008	Suburban	Chassis	EBCM Under 8600 GVW																																								
K	2008	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2008	Suburban	Chassis	Electronic Suspension Control																																								
K	2008	Suburban	Chassis	Trailer Brake Control Module																																								
K	2008	Suburban	Body	Amplifier (Bose)																																								
K	2008	Suburban	Body	Assist Step Controller																																								
K	2008	Suburban	Body	Body Control Module																																								
K	2008	Suburban	Body	Body Control Module (aux.)																																								
K	2008	Suburban	Body	Digital Radio Receiver																																								
K	2008	Suburban	Body	Driver Door Switch																																								
K	2008	Suburban	Body	HVAC Control Module Auto																																								
K	2008	Suburban	Body	HVAC Control Module Manual																																								
K	2008	Suburban	Body	Instrument Panel Cluster																																								
K	2008	Suburban	Body	Lift Gate Module																																								
K	2008	Suburban	Body	Memory Seat Module																																								
K	2008	Suburban	Body	Park Assist Module																																								
K	2008	Suburban	Body	Passenger Door Switch																																								
K	2008	Suburban	Body	Passenger Presence System																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2008	Suburban	Body	Radio																																								
K	2008	Suburban	Body	Rear Heated Seat Module																																								
K	2008	Suburban	Body	Rear HVAC/RSA																																								
K	2008	Suburban	Body	Rollover Sensor																																								
K	2008	Suburban	Body	Supplemental Inflatable Restraint																																								
K	2008	Suburban	Body	Theft Deterrent Module																																								
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
K	2008	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																								
K	2008	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2008	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2008	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2008	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																								
K	2008	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2008	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2008	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																								
K	2008	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
K	2008	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2008	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2008	Silverado	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2008	Silverado	Chassis	Electronic Suspension Control																																								
K	2008	Silverado	Chassis	Trailer Brake Control Module																																								
K	2008	Silverado	Body	Amplifier (Bose)																																								
K	2008	Silverado	Body	Body Control Module																																								
K	2008	Silverado	Body	Body Control Module (aux.)																																								
K	2008	Silverado	Body	Digital Radio Receiver																																								
K	2008	Silverado	Body	Driver Door Switch																																								
K	2008	Silverado	Body	HVAC Control Module Auto																																								
K	2008	Silverado	Body	HVAC Control Module Manual																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2008	Silverado	Body	Instrument Panel Cluster																																								
K	2008	Silverado	Body	Memory Seat Module																																								
K	2008	Silverado	Body	Park Assist Module																																								
K	2008	Silverado	Body	Passenger Door Switch																																								
K	2008	Silverado	Body	Passenger Presence System																																								
K	2008	Silverado	Body	Radio																																								
K	2008	Silverado	Body	Rear Heated Seat Module																																								
K	2008	Silverado	Body	Rear HVAC/RSA																																								
K	2008	Silverado	Body	Rollover Sensor																																								
K	2008	Silverado	Body	Supplemental Inflatable Restraint																																								
K	2008	Silverado	Body	Theft Deterrent Module																																								
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
K	2008	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2008	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2008	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2008	Tahoe	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																								
K	2008	Tahoe	Chassis	Electronic Brake Control Module																																								
K	2008	Tahoe	Chassis	Electronic Suspension Control																																								
K	2008	Tahoe	Chassis	Trailer Brake Control Module																																								
K	2008	Tahoe	Body	Amplifier (Bose)																																								
K	2008	Tahoe	Body	Assist Step Controller																																								
K	2008	Tahoe	Body	Body Control Module																																								
K	2008	Tahoe	Body	Body Control Module (aux.)																																								
K	2008	Tahoe	Body	Digital Radio Receiver																																								
K	2008	Tahoe	Body	Driver Door Switch																																								
K	2008	Tahoe	Body	HVAC Control Module Auto																																								
K	2008	Tahoe	Body	HVAC Control Module Manual																																								
K	2008	Tahoe	Body	Instrument Panel Cluster																																								
K	2008	Tahoe	Body	Lift Gate Module																																								
K	2008	Tahoe	Body	Memory Seat Module																																								
K	2008	Tahoe	Body	Park Assist Module																																								
K	2008	Tahoe	Body	Passenger Door Switch																																								
K	2008	Tahoe	Body	Passenger Presence System																																								
K	2008	Tahoe	Body	Radio																																								
K	2008	Tahoe	Body	Rear Heated Seat Module																																								
K	2008	Tahoe	Body	Rear HVAC/RSA																																								
K	2008	Tahoe	Body	Rollover Sensor																																								
K	2008	Tahoe	Body	Supplemental Inflatable Restraint																																								
K	2008	Tahoe	Body	Theft Deterrent Module																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2008	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2008	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																								
K	2008	Tahoe Hybrid	Chassis	Electronic Suspension Control																																								
K	2008	Tahoe Hybrid	Chassis	Power Steering Control Module																																								
K	2008	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																								
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																								
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																								
K	2008	Tahoe Hybrid	Body	A/C Compressor Control Module																																								
K	2008	Tahoe Hybrid	Body	Amplifier (Bose)																																								
K	2008	Tahoe Hybrid	Body	Body Control Module																																								
K	2008	Tahoe Hybrid	Body	Body Control Module (aux.)																																								
K	2008	Tahoe Hybrid	Body	Digital Radio Receiver																																								
K	2008	Tahoe Hybrid	Body	Driver Door Switch																																								
K	2008	Tahoe Hybrid	Body	HVAC Control Module																																								
K	2008	Tahoe Hybrid	Body	Instrument Panel Cluster																																								
K	2008	Tahoe Hybrid	Body	Lift Gate Module																																								
K	2008	Tahoe Hybrid	Body	Memory Seat Module																																								
K	2008	Tahoe Hybrid	Body	Park Assist Module																																								
K	2008	Tahoe Hybrid	Body	Passenger Door Switch																																								
K	2008	Tahoe Hybrid	Body	Passenger Presence System																																								
K	2008	Tahoe Hybrid	Body	Radio																																								
K	2008	Tahoe Hybrid	Body	Rear Heated Seat Module																																								
K	2008	Tahoe Hybrid	Body	Rear HVAC/RSA																																								
K	2008	Tahoe Hybrid	Body	Rollover Sensor																																								
K	2008	Tahoe Hybrid	Body	Serial Data Gateway Module																																								
K	2008	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2008	Tahoe Hybrid	Body	Theft Deterrent Module																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																								
K	2009	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																								
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 4 Speed																																								
K	2009	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module 6 Speed																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																								
K	2009	Avalanche	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																								
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2009	Avalanche	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2009	Avalanche	Chassis	Electronic Brake Control Module																																								
K	2009	Avalanche	Chassis	Electronic Suspension Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2009	Avalanche	Chassis	Trailer Brake Control Module																																								
K	2009	Avalanche	Body	Amplifier (Bose)																																								
K	2009	Avalanche	Body	Assist Step Controller																																								
K	2009	Avalanche	Body	Body Control Module																																								
K	2009	Avalanche	Body	Body Control Module (aux.)																																								
K	2009	Avalanche	Body	Digital Radio Receiver																																								
K	2009	Avalanche	Body	Driver Door Switch																																								
K	2009	Avalanche	Body	HVAC Control Module Auto																																								
K	2009	Avalanche	Body	HVAC Control Module Manual																																								
K	2009	Avalanche	Body	Instrument Panel Cluster																																								
K	2009	Avalanche	Body	Memory Seat Module																																								
K	2009	Avalanche	Body	Park Assist Module																																								
K	2009	Avalanche	Body	Passenger Door Switch																																								
K	2009	Avalanche	Body	Passenger Presence System																																								
K	2009	Avalanche	Body	Radio																																								
K	2009	Avalanche	Body	Rear Heated Seat Module																																								
K	2009	Avalanche	Body	Rear HVAC/RSA																																								
K	2009	Avalanche	Body	Rollover Sensor																																								
K	2009	Avalanche	Body	Supplemental Inflatable Restraint																																								
K	2009	Avalanche	Body	Theft Deterrent Module																																								
K	2009	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2009	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2009	Cheyenne	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
K	2009	Cheyenne	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																								
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2009	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
K	2009	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																								
K	2009	Cheyenne	Chassis	Trailer Brake Control Module																																								
K	2009	Cheyenne	Body	Amplifier (Bose)																																								
K	2009	Cheyenne	Body	Body Control Module (aux.)																																								
K	2009	Cheyenne	Body	Digital Radio Receiver																																								
K	2009	Cheyenne	Body	Driver Door Switch																																								
K	2009	Cheyenne	Body	Instrument Panel Cluster																																								
K	2009	Cheyenne	Body	Park Assist Module																																								
K	2009	Cheyenne	Body	Passenger Door Switch																																								
K	2009	Cheyenne	Body	Passenger Presence System																																								
K	2009	Cheyenne	Body	Rear Heated Seat Module																																								
K	2009	Cheyenne	Body	Rear HVAC/RSA																																								
K	2009	Cheyenne	Body	Rollover Sensor																																								
K	2009	Cheyenne	Body	Supplemental Inflatable Restraint																																								
K	2009	Cheyenne	Body	Theft Deterrent Module																																								
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2009	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2009	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2009	Suburban	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2009	Suburban	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2009	Suburban	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2009	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2009	Suburban	Chassis	EBCM Under 8600 GVW																																								
K	2009	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2009	Suburban	Chassis	Electronic Suspension Control																																								
K	2009	Suburban	Chassis	Trailer Brake Control Module																																								
K	2009	Suburban	Body	Amplifier (Bose)																																								
K	2009	Suburban	Body	Assist Step Controller																																								
K	2009	Suburban	Body	Body Control Module																																								
K	2009	Suburban	Body	Body Control Module (aux.)																																								
K	2009	Suburban	Body	Digital Radio Receiver																																								
K	2009	Suburban	Body	Driver Door Switch																																								
K	2009	Suburban	Body	HVAC Control Module Auto																																								
K	2009	Suburban	Body	HVAC Control Module Manual																																								
K	2009	Suburban	Body	Instrument Panel Cluster																																								
K	2009	Suburban	Body	Left Side Object Detection Module																																								
K	2009	Suburban	Body	Lift Gate Module																																								
K	2009	Suburban	Body	Memory Seat Module																																								
K	2009	Suburban	Body	Park Assist Module																																								
K	2009	Suburban	Body	Passenger Door Switch																																								
K	2009	Suburban	Body	Passenger Presence System																																								
K	2009	Suburban	Body	Radio																																								
K	2009	Suburban	Body	Rear Heated Seat Module																																								
K	2009	Suburban	Body	Rear HVAC/RSA																																								
K	2009	Suburban	Body	Right Side Object Detection Module																																								
K	2009	Suburban	Body	Rollover Sensor																																								
K	2009	Suburban	Body	Supplemental Inflatable Restraint																																								
K	2009	Suburban	Body	Theft Deterrent Module																																								
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
K	2009	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																								
K	2009	Silverado	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																								
K	2009	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																								
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2009	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																								
K	2009	Silverado	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																								
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																								
K	2009	Silverado	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2009	Silverado	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																								
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																								
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2009	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
K	2009	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																								
K	2009	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
K	2009	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2009	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																								
K	2009	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
K	2009	Silverado	Chassis	Electronic Suspension Control																																								
K	2009	Silverado	Chassis	Trailer Brake Control Module																																								
K	2009	Silverado	Body	Amplifier (Bose)																																								
K	2009	Silverado	Body	Body Control Module																																								
K	2009	Silverado	Body	Body Control Module (aux.)																																								
K	2009	Silverado	Body	Digital Radio Receiver																																								
K	2009	Silverado	Body	Driver Door Switch																																								
K	2009	Silverado	Body	HVAC Control Module Auto																																								
K	2009	Silverado	Body	HVAC Control Module Manual																																								
K	2009	Silverado	Body	Instrument Panel Cluster																																								
K	2009	Silverado	Body	Memory Seat Module																																								
K	2009	Silverado	Body	Park Assist Module																																								
K	2009	Silverado	Body	Passenger Door Switch																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2009	Silverado	Body	Passenger Presence System																																								
K	2009	Silverado	Body	Radio																																								
K	2009	Silverado	Body	Rear Heated Seat Module																																								
K	2009	Silverado	Body	Rear HVAC/RSA																																								
K	2009	Silverado	Body	Rollover Sensor																																								
K	2009	Silverado	Body	Supplemental Inflatable Restraint																																								
K	2009	Silverado	Body	Theft Deterrent Module																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2009	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2009	Silverado Hybrid	Chassis	Electronic Brake Control Module																																								
K	2009	Silverado Hybrid	Chassis	Electronic Suspension Control																																								
K	2009	Silverado Hybrid	Chassis	Power Steering Control Module																																								
K	2009	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2009	Silverado Hybrid	Body	A/C Compressor Control Module																																								
K	2009	Silverado Hybrid	Body	Amplifier (Bose)																																								
K	2009	Silverado Hybrid	Body	Body Control Module																																								
K	2009	Silverado Hybrid	Body	Body Control Module (aux.)																																								
K	2009	Silverado Hybrid	Body	Digital Radio Receiver																																								
K	2009	Silverado Hybrid	Body	Driver Door Switch																																								
K	2009	Silverado Hybrid	Body	HVAC Control Module																																								
K	2009	Silverado Hybrid	Body	Instrument Panel Cluster																																								
K	2009	Silverado Hybrid	Body	Memory Seat Module																																								
K	2009	Silverado Hybrid	Body	Park Assist Module																																								
K	2009	Silverado Hybrid	Body	Passenger Door Switch																																								
K	2009	Silverado Hybrid	Body	Passenger Presence System																																								
K	2009	Silverado Hybrid	Body	Radio																																								
K	2009	Silverado Hybrid	Body	Rear Heated Seat Module																																								
K	2009	Silverado Hybrid	Body	Rear HVAC/RSA																																								
K	2009	Silverado Hybrid	Body	Rollover Sensor																																								
K	2009	Silverado Hybrid	Body	Serial Data Gateway Module																																								
K	2009	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2009	Silverado Hybrid	Body	Theft Deterrent Module																																								
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																								
K	2009	Tahoe	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																								
K	2009	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																								
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2009	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																								
K	2009	Tahoe	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																								
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
K	2009	Tahoe	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2009	Tahoe	Chassis	Electronic Brake Control Module																																								
K	2009	Tahoe	Chassis	Electronic Suspension Control																																								
K	2009	Tahoe	Chassis	Trailer Brake Control Module																																								
K	2009	Tahoe	Body	Amplifier (Bose)																																								
K	2009	Tahoe	Body	Assist Step Controller																																								
K	2009	Tahoe	Body	Body Control Module																																								
K	2009	Tahoe	Body	Body Control Module (aux.)																																								
K	2009	Tahoe	Body	Digital Radio Receiver																																								
K	2009	Tahoe	Body	Driver Door Switch																																								
K	2009	Tahoe	Body	HVAC Control Module Auto																																								
K	2009	Tahoe	Body	HVAC Control Module Manual																																								
K	2009	Tahoe	Body	Instrument Panel Cluster																																								
K	2009	Tahoe	Body	Left Side Object Detection Module																																								
K	2009	Tahoe	Body	Lift Gate Module																																								
K	2009	Tahoe	Body	Memory Seat Module																																								
K	2009	Tahoe	Body	Park Assist Module																																								
K	2009	Tahoe	Body	Passenger Door Switch																																								
K	2009	Tahoe	Body	Passenger Presence System																																								
K	2009	Tahoe	Body	Radio																																								
K	2009	Tahoe	Body	Rear Heated Seat Module																																								
K	2009	Tahoe	Body	Rear HVAC/RSA																																								
K	2009	Tahoe	Body	Right Side Object Detection Module																																								
K	2009	Tahoe	Body	Rollover Sensor																																								
K	2009	Tahoe	Body	Supplemental Inflatable Restraint																																								
K	2009	Tahoe	Body	Theft Deterrent Module																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2009	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2009	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																								
K	2009	Tahoe Hybrid	Chassis	Electronic Suspension Control																																								
K	2009	Tahoe Hybrid	Chassis	Power Steering Control Module																																								
K	2009	Tahoe Hybrid	Chassis	Trailer Brake Control Module																																								
K	2009	Tahoe Hybrid	Body	A/C Compressor Control Module																																								
K	2009	Tahoe Hybrid	Body	Amplifier (Bose)																																								
K	2009	Tahoe Hybrid	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2009	Tahoe Hybrid	Body	Body Control Module (aux.)																																								
K	2009	Tahoe Hybrid	Body	Digital Radio Receiver																																								
K	2009	Tahoe Hybrid	Body	Driver Door Switch																																								
K	2009	Tahoe Hybrid	Body	Heated Seat Module																																								
K	2009	Tahoe Hybrid	Body	HVAC Control Module																																								
K	2009	Tahoe Hybrid	Body	Instrument Panel Cluster																																								
K	2009	Tahoe Hybrid	Body	Left Side Object Detection Module																																								
K	2009	Tahoe Hybrid	Body	Park Assist Module																																								
K	2009	Tahoe Hybrid	Body	Passenger Door Switch																																								
K	2009	Tahoe Hybrid	Body	Passenger Presence System																																								
K	2009	Tahoe Hybrid	Body	Radio																																								
K	2009	Tahoe Hybrid	Body	Rear Heated Seat Module																																								
K	2009	Tahoe Hybrid	Body	Rear HVAC/RSA																																								
K	2009	Tahoe Hybrid	Body	Right Side Object Detection Module																																								
K	2009	Tahoe Hybrid	Body	Rollover Sensor																																								
K	2009	Tahoe Hybrid	Body	Serial Data Gateway Module																																								
K	2009	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2009	Tahoe Hybrid	Body	Theft Deterrent Module																																								
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2010	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																								
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																								
K	2010	Avalanche	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2010	Avalanche	Chassis	Electronic Brake Control Module																																								
K	2010	Avalanche	Chassis	Electronic Suspension Control																																								
K	2010	Avalanche	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Avalanche	Body	Amplifier (Bose)																																								
K	2010	Avalanche	Body	Assist Step Controller																																								
K	2010	Avalanche	Body	Body Control Module																																								
K	2010	Avalanche	Body	Body Control Module (aux.)																																								
K	2010	Avalanche	Body	Digital Radio Receiver																																								
K	2010	Avalanche	Body	Driver Door Switch																																								
K	2010	Avalanche	Body	HVAC Control Module Auto																																								
K	2010	Avalanche	Body	HVAC Control Module Manual																																								
K	2010	Avalanche	Body	Instrument Panel Cluster																																								
K	2010	Avalanche	Body	Memory Seat Module																																								
K	2010	Avalanche	Body	Park Assist Module																																								
K	2010	Avalanche	Body	Passenger Door Switch																																								
K	2010	Avalanche	Body	Passenger Presence System																																								
K	2010	Avalanche	Body	Radio																																								
K	2010	Avalanche	Body	Rear Heated Seat Module																																								
K	2010	Avalanche	Body	Rear HVAC/RSA																																								
K	2010	Avalanche	Body	Supplemental Inflatable Restraint																																								
K	2010	Avalanche	Body	Theft Deterrent Module																																								
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2010	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2010	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2010	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																								
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
K	2010	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																								
K	2010	Cheyenne	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Cheyenne	Body	Amplifier (Bose)																																								
K	2010	Cheyenne	Body	Body Control Module (aux.)																																								
K	2010	Cheyenne	Body	Digital Radio Receiver																																								
K	2010	Cheyenne	Body	Driver Door Switch																																								
K	2010	Cheyenne	Body	Instrument Panel Cluster																																								
K	2010	Cheyenne	Body	Park Assist Module																																								
K	2010	Cheyenne	Body	Passenger Door Switch																																								
K	2010	Cheyenne	Body	Passenger Presence System																																								
K	2010	Cheyenne	Body	Rear Heated Seat Module																																								
K	2010	Cheyenne	Body	Rear HVAC/RSA																																								
K	2010	Cheyenne	Body	Supplemental Inflatable Restraint																																								
K	2010	Cheyenne	Body	Theft Deterrent Module																																								
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2010	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																								
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																								
K	2010	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
K	2010	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																								
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																								
K	2010	Suburban	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2010	Suburban	Chassis	EBCM Under 8600 GVW																																								
K	2010	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2010	Suburban	Chassis	Electronic Suspension Control																																								
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Suburban	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Suburban	Body	Amplifier (Bose)																																								
K	2010	Suburban	Body	Assist Step Controller																																								
K	2010	Suburban	Body	Body Control Module																																								
K	2010	Suburban	Body	Body Control Module (aux.)																																								
K	2010	Suburban	Body	Digital Radio Receiver																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2010	Suburban	Body	Driver Door Switch																																								
K	2010	Suburban	Body	HVAC Control Module Auto																																								
K	2010	Suburban	Body	HVAC Control Module Manual																																								
K	2010	Suburban	Body	Instrument Panel Cluster																																								
K	2010	Suburban	Body	Left Side Object Detection Module																																								
K	2010	Suburban	Body	Lift Gate Module																																								
K	2010	Suburban	Body	Memory Seat Module																																								
K	2010	Suburban	Body	Park Assist Module																																								
K	2010	Suburban	Body	Passenger Door Switch																																								
K	2010	Suburban	Body	Passenger Presence System																																								
K	2010	Suburban	Body	Radio																																								
K	2010	Suburban	Body	Rear Heated Seat Module																																								
K	2010	Suburban	Body	Rear HVAC/RSA																																								
K	2010	Suburban	Body	Right Side Object Detection Module																																								
K	2010	Suburban	Body	Supplemental Inflatable Restraint																																								
K	2010	Suburban	Body	Theft Deterrent Module																																								
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																								
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																								
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
K	2010	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																								
K	2010	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2010	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2010	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
K	2010	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Automatic																																								
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																								
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2010	Silverado	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
K	2010	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																								
K	2010	Silverado	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
K	2010	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2010	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2010	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
K	2010	Silverado	Chassis	Electronic Suspension Control																																								
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																								
K	2010	Silverado	Chassis	FPCM With Trailer Brake Control																																								
K	2010	Silverado	Body	Amplifier (Bose)																																								
K	2010	Silverado	Body	Body Control Module																																								
K	2010	Silverado	Body	Body Control Module (aux.)																																								
K	2010	Silverado	Body	Digital Radio Receiver																																								
K	2010	Silverado	Body	Driver Door Switch																																								
K	2010	Silverado	Body	HVAC Control Module Auto																																								
K	2010	Silverado	Body	HVAC Control Module Manual																																								
K	2010	Silverado	Body	Instrument Panel Cluster																																								
K	2010	Silverado	Body	Memory Seat Module																																								
K	2010	Silverado	Body	Park Assist Module																																								
K	2010	Silverado	Body	Passenger Door Switch																																								
K	2010	Silverado	Body	Passenger Presence System																																								
K	2010	Silverado	Body	Radio																																								
K	2010	Silverado	Body	Rear Heated Seat Module																																								
K	2010	Silverado	Body	Rear HVAC/RSA																																								
K	2010	Silverado	Body	Supplemental Inflatable Restraint																																								
K	2010	Silverado	Body	Theft Deterrent Module																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2010	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2010	Silverado Hybrid	Chassis	Electronic Brake Control Module																																								
K	2010	Silverado Hybrid	Chassis	Electronic Suspension Control																																								
K	2010	Silverado Hybrid	Chassis	Power Steering Control Module																																								
K	2010	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Silverado Hybrid	Body	A/C Compressor Control Module																																								
K	2010	Silverado Hybrid	Body	Amplifier (Bose)																																								
K	2010	Silverado Hybrid	Body	Body Control Module																																								
K	2010	Silverado Hybrid	Body	Body Control Module (aux.)																																								
K	2010	Silverado Hybrid	Body	Digital Radio Receiver																																								
K	2010	Silverado Hybrid	Body	Driver Door Switch																																								
K	2010	Silverado Hybrid	Body	Heated Seat Module																																								
K	2010	Silverado Hybrid	Body	HVAC Control Module																																								
K	2010	Silverado Hybrid	Body	Instrument Panel Cluster																																								
K	2010	Silverado Hybrid	Body	Park Assist Module																																								
K	2010	Silverado Hybrid	Body	Passenger Door Switch																																								
K	2010	Silverado Hybrid	Body	Passenger Presence System																																								
K	2010	Silverado Hybrid	Body	Radio																																								
K	2010	Silverado Hybrid	Body	Rear Heated Seat Module																																								
K	2010	Silverado Hybrid	Body	Rear HVAC/RSA																																								
K	2010	Silverado Hybrid	Body	Serial Data Gateway Module																																								
K	2010	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2010	Silverado Hybrid	Body	Theft Deterrent Module																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2010	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																								
K	2010	Tahoe	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2010	Tahoe	Chassis	Electronic Brake Control Module																																								
K	2010	Tahoe	Chassis	Electronic Suspension Control																																								
K	2010	Tahoe	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Tahoe	Body	Amplifier (Bose)																																								
K	2010	Tahoe	Body	Assist Step Controller																																								
K	2010	Tahoe	Body	Body Control Module																																								
K	2010	Tahoe	Body	Body Control Module (aux.)																																								
K	2010	Tahoe	Body	Digital Radio Receiver																																								
K	2010	Tahoe	Body	Driver Door Switch																																								
K	2010	Tahoe	Body	HVAC Control Module Auto																																								
K	2010	Tahoe	Body	HVAC Control Module Manual																																								
K	2010	Tahoe	Body	Instrument Panel Cluster																																								
K	2010	Tahoe	Body	Left Side Object Detection Module																																								
K	2010	Tahoe	Body	Lift Gate Module																																								
K	2010	Tahoe	Body	Memory Seat Module																																								
K	2010	Tahoe	Body	Park Assist Module																																								
K	2010	Tahoe	Body	Passenger Door Switch																																								
K	2010	Tahoe	Body	Passenger Presence System																																								
K	2010	Tahoe	Body	Radio																																								
K	2010	Tahoe	Body	Rear Heated Seat Module																																								
K	2010	Tahoe	Body	Rear HVAC/RSA																																								
K	2010	Tahoe	Body	Right Side Object Detection Module																																								
K	2010	Tahoe	Body	Supplemental Inflatable Restraint																																								
K	2010	Tahoe	Body	Theft Deterrent Module																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2010	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2010	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																								
K	2010	Tahoe Hybrid	Chassis	Electronic Suspension Control																																								
K	2010	Tahoe Hybrid	Chassis	Power Steering Control Module																																								
K	2010	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Tahoe Hybrid	Body	A/C Compressor Control Module																																								
K	2010	Tahoe Hybrid	Body	Amplifier (Bose)																																								
K	2010	Tahoe Hybrid	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2010	Tahoe Hybrid	Body	Body Control Module (aux.)																																								
K	2010	Tahoe Hybrid	Body	Digital Radio Receiver																																								
K	2010	Tahoe Hybrid	Body	Driver Door Switch																																								
K	2010	Tahoe Hybrid	Body	Heated Seat Module																																								
K	2010	Tahoe Hybrid	Body	HVAC Control Module																																								
K	2010	Tahoe Hybrid	Body	Instrument Panel Cluster																																								
K	2010	Tahoe Hybrid	Body	Left Side Object Detection Module																																								
K	2010	Tahoe Hybrid	Body	Lift Gate Module																																								
K	2010	Tahoe Hybrid	Body	Park Assist Module																																								
K	2010	Tahoe Hybrid	Body	Passenger Door Switch																																								
K	2010	Tahoe Hybrid	Body	Passenger Presence System																																								
K	2010	Tahoe Hybrid	Body	Radio																																								
K	2010	Tahoe Hybrid	Body	Rear Heated Seat Module																																								
K	2010	Tahoe Hybrid	Body	Rear HVAC/RSA																																								
K	2010	Tahoe Hybrid	Body	Right Side Object Detection Module																																								
K	2010	Tahoe Hybrid	Body	Serial Data Gateway Module																																								
K	2010	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2010	Tahoe Hybrid	Body	Theft Deterrent Module																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																								
K	2011	Avalanche	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Engine Control Module																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Engine Control Module																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2011	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2011	Avalanche	Chassis	Electronic Brake Control Module																																								
K	2011	Avalanche	Chassis	Electronic Suspension Control																																								
K	2011	Avalanche	Chassis	FPCM with Trailer Brake Control																																								
K	2011	Avalanche	Body	Amplifier (Bose)																																								
K	2011	Avalanche	Body	Assist Step Controller																																								
K	2011	Avalanche	Body	Body Control Module																																								
K	2011	Avalanche	Body	Body Control Module (aux.)																																								
K	2011	Avalanche	Body	Digital Radio Receiver																																								
K	2011	Avalanche	Body	Driver Door Switch																																								
K	2011	Avalanche	Body	HVAC Control Module Auto																																								
K	2011	Avalanche	Body	HVAC Control Module Manual																																								
K	2011	Avalanche	Body	Instrument Panel Cluster																																								
K	2011	Avalanche	Body	Memory Seat Module																																								
K	2011	Avalanche	Body	Park Assist Module																																								
K	2011	Avalanche	Body	Passenger Door Switch																																								
K	2011	Avalanche	Body	Passenger Presence System																																								
K	2011	Avalanche	Body	Radio																																								
K	2011	Avalanche	Body	Rear Heated Seat Module																																								
K	2011	Avalanche	Body	Rear HVAC/RSA																																								
K	2011	Avalanche	Body	Supplemental Inflatable Restraint																																								
K	2011	Avalanche	Body	Theft Deterrent Module																																								
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2011	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2011	Cheyenne	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2011	Cheyenne	Chassis	EBCM Under 8600 GVW without VSES																																								
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
K	2011	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																								
K	2011	Cheyenne	Chassis	Electronic Suspension Control																																								
K	2011	Cheyenne	Chassis	FPCM with Trailer Brake Control																																								
K	2011	Cheyenne	Body	Amplifier (Bose)																																								
K	2011	Cheyenne	Body	Body Control Module																																								
K	2011	Cheyenne	Body	Body Control Module (aux.)																																								
K	2011	Cheyenne	Body	Digital Radio Receiver																																								
K	2011	Cheyenne	Body	Driver Door Switch																																								
K	2011	Cheyenne	Body	Instrument Panel Cluster																																								
K	2011	Cheyenne	Body	Park Assist Module																																								
K	2011	Cheyenne	Body	Passenger Door Switch																																								
K	2011	Cheyenne	Body	Passenger Presence System																																								
K	2011	Cheyenne	Body	Rear Heated Seat Module																																								
K	2011	Cheyenne	Body	Rear HVAC/RSA																																								
K	2011	Cheyenne	Body	Supplemental Inflatable Restraint																																								
K	2011	Cheyenne	Body	Theft Deterrent Module																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2011	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																								
K	2011	Suburban	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
K	2011	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
K	2011	Suburban	Chassis	EBCM Under 8600 GVW																																								
K	2011	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2011	Suburban	Chassis	Electronic Suspension Control																																								
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																								
K	2011	Suburban	Chassis	FPCM with Trailer Brake Control																																								
K	2011	Suburban	Body	Amplifier (Bose)																																								
K	2011	Suburban	Body	Assist Step Controller																																								
K	2011	Suburban	Body	Body Control Module																																								
K	2011	Suburban	Body	Body Control Module (aux.)																																								
K	2011	Suburban	Body	Digital Radio Receiver																																								
K	2011	Suburban	Body	Driver Door Switch																																								
K	2011	Suburban	Body	HVAC Control Module Auto																																								
K	2011	Suburban	Body	HVAC Control Module Manual																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2011	Suburban	Body	Instrument Panel Cluster																																								
K	2011	Suburban	Body	Left Side Object Detection Module																																								
K	2011	Suburban	Body	Lift Gate Module																																								
K	2011	Suburban	Body	Memory Seat Module																																								
K	2011	Suburban	Body	Park Assist Module																																								
K	2011	Suburban	Body	Passenger Door Switch																																								
K	2011	Suburban	Body	Passenger Presence System																																								
K	2011	Suburban	Body	Radio																																								
K	2011	Suburban	Body	Rear Heated Seat Module																																								
K	2011	Suburban	Body	Rear HVAC/RSA																																								
K	2011	Suburban	Body	Right Side Object Detection Module																																								
K	2011	Suburban	Body	Supplemental Inflatable Restraint																																								
K	2011	Suburban	Body	Theft Deterrent Module																																								
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																								
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																								
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
K	2011	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																								
K	2011	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (NO)Engine Control Module																																								
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Manual Transfer Case (YES)Engine Control Module																																								
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2011	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2011	Silverado	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																								
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																								
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
K	2011	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
K	2011	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																								
K	2011	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																								
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																								
K	2011	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
K	2011	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2011	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2011	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
K	2011	Silverado	Chassis	Electronic Suspension Control																																								
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																								
K	2011	Silverado	Chassis	FPCM With Trailer Brake Control																																								
K	2011	Silverado	Body	Amplifier (Bose)																																								
K	2011	Silverado	Body	Body Control Module																																								
K	2011	Silverado	Body	Body Control Module (aux.)																																								
K	2011	Silverado	Body	Digital Radio Receiver																																								
K	2011	Silverado	Body	Driver Door Switch																																								
K	2011	Silverado	Body	HVAC Control Module Auto																																								
K	2011	Silverado	Body	HVAC Control Module Manual																																								
K	2011	Silverado	Body	Instrument Panel Cluster																																								
K	2011	Silverado	Body	Memory Seat Module																																								
K	2011	Silverado	Body	Park Assist Module																																								
K	2011	Silverado	Body	Passenger Door Switch																																								
K	2011	Silverado	Body	Passenger Presence System																																								
K	2011	Silverado	Body	Radio																																								
K	2011	Silverado	Body	Rear Heated Seat Module																																								
K	2011	Silverado	Body	Rear HVAC/RSA																																								
K	2011	Silverado	Body	Supplemental Inflatable Restraint																																								
K	2011	Silverado	Body	Theft Deterrent Module																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2011	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2011	Silverado Hybrid	Chassis	Electronic Brake Control Module																																								
K	2011	Silverado Hybrid	Chassis	Electronic Suspension Control																																								
K	2011	Silverado Hybrid	Chassis	Power Steering Control Module																																								
K	2011	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2011	Silverado Hybrid	Body	A/C Compressor Control Module																																								
K	2011	Silverado Hybrid	Body	Amplifier (Bose)																																								
K	2011	Silverado Hybrid	Body	Body Control Module																																								
K	2011	Silverado Hybrid	Body	Body Control Module (aux.)																																								
K	2011	Silverado Hybrid	Body	Digital Radio Receiver																																								
K	2011	Silverado Hybrid	Body	Driver Door Switch																																								
K	2011	Silverado Hybrid	Body	Heated Seat Module																																								
K	2011	Silverado Hybrid	Body	HVAC Control Module																																								
K	2011	Silverado Hybrid	Body	Instrument Panel Cluster																																								
K	2011	Silverado Hybrid	Body	Park Assist Module																																								
K	2011	Silverado Hybrid	Body	Passenger Door Switch																																								
K	2011	Silverado Hybrid	Body	Passenger Presence System																																								
K	2011	Silverado Hybrid	Body	Radio																																								
K	2011	Silverado Hybrid	Body	Rear Heated Seat Module																																								
K	2011	Silverado Hybrid	Body	Rear HVAC/RSA																																								
K	2011	Silverado Hybrid	Body	Serial Data Gateway Module																																								
K	2011	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2011	Silverado Hybrid	Body	Theft Deterrent Module																																								
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2011	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2011	Tahoe	Chassis	Electronic Brake Control Module																																								
K	2011	Tahoe	Chassis	Electronic Suspension Control																																								
K	2011	Tahoe	Chassis	FPCM with Trailer Brake Control																																								
K	2011	Tahoe	Body	Amplifier (Bose)																																								
K	2011	Tahoe	Body	Assist Step Controller																																								
K	2011	Tahoe	Body	Body Control Module																																								
K	2011	Tahoe	Body	Body Control Module (aux.)																																								
K	2011	Tahoe	Body	Digital Radio Receiver																																								
K	2011	Tahoe	Body	Driver Door Switch																																								
K	2011	Tahoe	Body	HVAC Control Module Auto																																								
K	2011	Tahoe	Body	HVAC Control Module Manual																																								
K	2011	Tahoe	Body	Instrument Panel Cluster																																								
K	2011	Tahoe	Body	Left Side Object Detection Module																																								
K	2011	Tahoe	Body	Lift Gate Module																																								
K	2011	Tahoe	Body	Memory Seat Module																																								
K	2011	Tahoe	Body	Park Assist Module																																								
K	2011	Tahoe	Body	Passenger Door Switch																																								
K	2011	Tahoe	Body	Passenger Presence System																																								
K	2011	Tahoe	Body	Radio																																								
K	2011	Tahoe	Body	Rear Heated Seat Module																																								
K	2011	Tahoe	Body	Rear HVAC/RSA																																								
K	2011	Tahoe	Body	Right Side Object Detection Module																																								
K	2011	Tahoe	Body	Supplemental Inflatable Restraint																																								
K	2011	Tahoe	Body	Theft Deterrent Module																																								
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2011	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2011	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																								
K	2011	Tahoe Hybrid	Chassis	Electronic Suspension Control																																								
K	2011	Tahoe Hybrid	Chassis	Power Steering Control Module																																								
K	2011	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2011	Tahoe Hybrid	Body	A/C Compressor Control Module																																								
K	2011	Tahoe Hybrid	Body	Amplifier (Bose)																																								
K	2011	Tahoe Hybrid	Body	Body Control Module																																								
K	2011	Tahoe Hybrid	Body	Body Control Module (aux.)																																								
K	2011	Tahoe Hybrid	Body	Digital Radio Receiver																																								
K	2011	Tahoe Hybrid	Body	Driver Door Switch																																								
K	2011	Tahoe Hybrid	Body	Heated Seat Module																																								
K	2011	Tahoe Hybrid	Body	HVAC Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2011	Tahoe Hybrid	Body	Instrument Panel Cluster																																								
K	2011	Tahoe Hybrid	Body	Left Side Object Detection Module																																								
K	2011	Tahoe Hybrid	Body	Lift Gate Module																																								
K	2011	Tahoe Hybrid	Body	Park Assist Module																																								
K	2011	Tahoe Hybrid	Body	Passenger Door Switch																																								
K	2011	Tahoe Hybrid	Body	Passenger Presence System																																								
K	2011	Tahoe Hybrid	Body	Radio																																								
K	2011	Tahoe Hybrid	Body	Rear Heated Seat Module																																								
K	2011	Tahoe Hybrid	Body	Rear HVAC/RSA																																								
K	2011	Tahoe Hybrid	Body	Right Side Object Detection Module																																								
K	2011	Tahoe Hybrid	Body	Serial Data Gateway Module																																								
K	2011	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2011	Tahoe Hybrid	Body	Theft Deterrent Module																																								
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																								
K	2012	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																								
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2012	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2012	Avalanche	Chassis	Electronic Brake Control Module																																								
K	2012	Avalanche	Chassis	Electronic Suspension Control																																								
K	2012	Avalanche	Chassis	FPCM with Trailer Brake Control																																								
K	2012	Avalanche	Body	Amplifier (Bose)																																								
K	2012	Avalanche	Body	Assist Step Controller																																								
K	2012	Avalanche	Body	Body Control Module																																								
K	2012	Avalanche	Body	Body Control Module (aux.)																																								
K	2012	Avalanche	Body	Digital Radio Receiver																																								
K	2012	Avalanche	Body	Driver Door Switch																																								
K	2012	Avalanche	Body	HVAC Control Module Auto																																								
K	2012	Avalanche	Body	HVAC Control Module Manual																																								
K	2012	Avalanche	Body	Instrument Panel Cluster																																								
K	2012	Avalanche	Body	Memory Seat Module																																								
K	2012	Avalanche	Body	Navigation Radio																																								
K	2012	Avalanche	Body	Park Assist Module																																								
K	2012	Avalanche	Body	Passenger Door Switch																																								
K	2012	Avalanche	Body	Passenger Presence System																																								
K	2012	Avalanche	Body	Radio																																								
K	2012	Avalanche	Body	Rear Heated Seat Module																																								
K	2012	Avalanche	Body	Rear HVAC/RSA																																								
K	2012	Avalanche	Body	Supplemental Inflatable Restraint																																								
K	2012	Avalanche	Body	Theft Deterrent Module																																								
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																								
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																								
K	2012	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2012	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																								
K	2012	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2012	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
K	2012	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																								
K	2012	Cheyenne	Chassis	Electronic Suspension Control																																								
K	2012	Cheyenne	Chassis	FPCM with Trailer Brake Control																																								
K	2012	Cheyenne	Body	Amplifier (Bose)																																								
K	2012	Cheyenne	Body	Body Control Module																																								
K	2012	Cheyenne	Body	Body Control Module (aux.)																																								
K	2012	Cheyenne	Body	Digital Radio Receiver																																								
K	2012	Cheyenne	Body	Driver Door Switch																																								
K	2012	Cheyenne	Body	Instrument Panel Cluster																																								
K	2012	Cheyenne	Body	Park Assist Module																																								
K	2012	Cheyenne	Body	Passenger Door Switch																																								
K	2012	Cheyenne	Body	Passenger Presence System																																								
K	2012	Cheyenne	Body	Rear Heated Seat Module																																								
K	2012	Cheyenne	Body	Rear HVAC/RSA																																								
K	2012	Cheyenne	Body	Supplemental Inflatable Restraint																																								
K	2012	Cheyenne	Body	Theft Deterrent Module																																								
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2012	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																								
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																								
K	2012	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
K	2012	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
K	2012	Suburban	Chassis	EBCM Under 8600 GVW																																								
K	2012	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2012	Suburban	Chassis	Electronic Suspension Control																																								
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																								
K	2012	Suburban	Chassis	FPCM with Trailer Brake Control																																								
K	2012	Suburban	Body	Amplifier (Bose)																																								
K	2012	Suburban	Body	Assist Step Controller																																								
K	2012	Suburban	Body	Body Control Module																																								
K	2012	Suburban	Body	Body Control Module (aux.)																																								
K	2012	Suburban	Body	Digital Radio Receiver																																								
K	2012	Suburban	Body	Driver Door Switch																																								
K	2012	Suburban	Body	HVAC Control Module Auto																																								
K	2012	Suburban	Body	HVAC Control Module Manual																																								
K	2012	Suburban	Body	Instrument Panel Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2012	Suburban	Body	Left Side Object Detection Module																																								
K	2012	Suburban	Body	Lift Gate Module																																								
K	2012	Suburban	Body	Memory Seat Module																																								
K	2012	Suburban	Body	Navigation Radio																																								
K	2012	Suburban	Body	Park Assist Module																																								
K	2012	Suburban	Body	Passenger Door Switch																																								
K	2012	Suburban	Body	Passenger Presence System																																								
K	2012	Suburban	Body	Radio																																								
K	2012	Suburban	Body	Rear Heated Seat Module																																								
K	2012	Suburban	Body	Rear HVAC/RSA																																								
K	2012	Suburban	Body	Right Side Object Detection Module																																								
K	2012	Suburban	Body	Supplemental Inflatable Restraint																																								
K	2012	Suburban	Body	Theft Deterrent Module																																								
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																								
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																								
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
K	2012	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																								
K	2012	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2012	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																								
K	2012	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																								
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																								
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
K	2012	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
K	2012	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																								
K	2012	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																								
K	2012	Silverado	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
K	2012	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2012	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																								
K	2012	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2012	Silverado	Chassis	Electronic Suspension Control																																								
K	2012	Silverado	Chassis	FPCM With Trailer Brake Control																																								
K	2012	Silverado	Body	Amplifier (Bose)																																								
K	2012	Silverado	Body	Body Control Module																																								
K	2012	Silverado	Body	Body Control Module (aux.)																																								
K	2012	Silverado	Body	Digital Radio Receiver																																								
K	2012	Silverado	Body	Driver Door Switch																																								
K	2012	Silverado	Body	HVAC Control Module Auto																																								
K	2012	Silverado	Body	HVAC Control Module Manual																																								
K	2012	Silverado	Body	Instrument Panel Cluster																																								
K	2012	Silverado	Body	Memory Seat Module																																								
K	2012	Silverado	Body	Navigation Radio																																								
K	2012	Silverado	Body	Park Assist Module																																								
K	2012	Silverado	Body	Passenger Door Switch																																								
K	2012	Silverado	Body	Passenger Presence System																																								
K	2012	Silverado	Body	Radio																																								
K	2012	Silverado	Body	Rear Heated Seat Module																																								
K	2012	Silverado	Body	Rear HVAC/RSA																																								
K	2012	Silverado	Body	Supplemental Inflatable Restraint																																								
K	2012	Silverado	Body	Theft Deterrent Module																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2012	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2012	Silverado Hybrid	Chassis	Electronic Brake Control Module																																								
K	2012	Silverado Hybrid	Chassis	Electronic Suspension Control																																								
K	2012	Silverado Hybrid	Chassis	Power Steering Control Module																																								
K	2012	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2012	Silverado Hybrid	Body	A/C Compressor Control Module																																								
K	2012	Silverado Hybrid	Body	Amplifier (Bose)																																								
K	2012	Silverado Hybrid	Body	Body Control Module																																								
K	2012	Silverado Hybrid	Body	Body Control Module (aux.)																																								
K	2012	Silverado Hybrid	Body	Digital Radio Receiver																																								
K	2012	Silverado Hybrid	Body	Driver Door Switch																																								
K	2012	Silverado Hybrid	Body	Heated Seat Module																																								
K	2012	Silverado Hybrid	Body	HVAC Control Module																																								
K	2012	Silverado Hybrid	Body	Instrument Panel Cluster																																								
K	2012	Silverado Hybrid	Body	Navigation Radio																																								
K	2012	Silverado Hybrid	Body	Park Assist Module																																								
K	2012	Silverado Hybrid	Body	Passenger Door Switch																																								
K	2012	Silverado Hybrid	Body	Passenger Presence System																																								
K	2012	Silverado Hybrid	Body	Radio																																								
K	2012	Silverado Hybrid	Body	Rear Heated Seat Module																																								
K	2012	Silverado Hybrid	Body	Rear HVAC/RSA																																								
K	2012	Silverado Hybrid	Body	Serial Data Gateway Module																																								
K	2012	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2012	Silverado Hybrid	Body	Theft Deterrent Module																																								
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2012	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2012	Tahoe	Chassis	EBCM with Trailer Brake																																								
K	2012	Tahoe	Chassis	Electronic Suspension Control																																								
K	2012	Tahoe	Chassis	FPCM with Trailer Brake Control																																								
K	2012	Tahoe	Body	Amplifier (Bose)																																								
K	2012	Tahoe	Body	Assist Step Controller																																								
K	2012	Tahoe	Body	Body Control Module																																								
K	2012	Tahoe	Body	Body Control Module (aux.)																																								
K	2012	Tahoe	Body	Digital Radio Receiver																																								
K	2012	Tahoe	Body	Driver Door Switch																																								
K	2012	Tahoe	Body	HVAC Control Module Auto																																								
K	2012	Tahoe	Body	HVAC Control Module Manual																																								
K	2012	Tahoe	Body	Instrument Panel Cluster																																								
K	2012	Tahoe	Body	Left Side Object Detection Module																																								
K	2012	Tahoe	Body	Lift Gate Module																																								
K	2012	Tahoe	Body	Memory Seat Module																																								
K	2012	Tahoe	Body	Navigation Radio																																								
K	2012	Tahoe	Body	Park Assist Module																																								
K	2012	Tahoe	Body	Passenger Door Switch																																								
K	2012	Tahoe	Body	Passenger Presence System																																								
K	2012	Tahoe	Body	Radio																																								
K	2012	Tahoe	Body	Rear Heated Seat Module																																								
K	2012	Tahoe	Body	Rear HVAC/RSA																																								
K	2012	Tahoe	Body	Right Side Object Detection Module																																								
K	2012	Tahoe	Body	Supplemental Inflatable Restraint																																								
K	2012	Tahoe	Body	Theft Deterrent Module																																								
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2012	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2012	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																								
K	2012	Tahoe Hybrid	Chassis	Electronic Suspension Control																																								
K	2012	Tahoe Hybrid	Chassis	Power Steering Control Module																																								
K	2012	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2012	Tahoe Hybrid	Body	A/C Compressor Control Module																																								
K	2012	Tahoe Hybrid	Body	Amplifier (Bose)																																								
K	2012	Tahoe Hybrid	Body	Body Control Module																																								
K	2012	Tahoe Hybrid	Body	Body Control Module (aux.)																																								
K	2012	Tahoe Hybrid	Body	Digital Radio Receiver																																								
K	2012	Tahoe Hybrid	Body	Driver Door Switch																																								
K	2012	Tahoe Hybrid	Body	Heated Seat Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2012	Tahoe Hybrid	Body	HVAC Control Module																																								
K	2012	Tahoe Hybrid	Body	Instrument Panel Cluster																																								
K	2012	Tahoe Hybrid	Body	Left Side Object Detection Module																																								
K	2012	Tahoe Hybrid	Body	Lift Gate Module																																								
K	2012	Tahoe Hybrid	Body	Navigation Radio																																								
K	2012	Tahoe Hybrid	Body	Park Assist Module																																								
K	2012	Tahoe Hybrid	Body	Passenger Door Switch																																								
K	2012	Tahoe Hybrid	Body	Passenger Presence System																																								
K	2012	Tahoe Hybrid	Body	Radio																																								
K	2012	Tahoe Hybrid	Body	Rear Heated Seat Module																																								
K	2012	Tahoe Hybrid	Body	Rear HVAC/RSA																																								
K	2012	Tahoe Hybrid	Body	Right Side Object Detection Module																																								
K	2012	Tahoe Hybrid	Body	Serial Data Gateway Module																																								
K	2012	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2012	Tahoe Hybrid	Body	Theft Deterrent Module																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																								
K	2013	Avalanche	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2013	Avalanche	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2013	Avalanche	Chassis	Electronic Brake Control Module																																								
K	2013	Avalanche	Chassis	Electronic Suspension Control																																								
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																								
K	2013	Avalanche	Chassis	FPCM with Trailer Brake Control																																								
K	2013	Avalanche	Body	Amplifier (Bose)																																								
K	2013	Avalanche	Body	Assist Step Controller																																								
K	2013	Avalanche	Body	Body Control Module																																								
K	2013	Avalanche	Body	Body Control Module (aux.)																																								
K	2013	Avalanche	Body	Digital Radio Receiver																																								
K	2013	Avalanche	Body	Driver Door Switch																																								
K	2013	Avalanche	Body	HVAC Control Module Auto																																								
K	2013	Avalanche	Body	HVAC Control Module Manual																																								
K	2013	Avalanche	Body	Instrument Panel Cluster																																								
K	2013	Avalanche	Body	Memory Seat Module																																								
K	2013	Avalanche	Body	Navigation Radio																																								
K	2013	Avalanche	Body	Park Assist Module																																								
K	2013	Avalanche	Body	Passenger Door Switch																																								
K	2013	Avalanche	Body	Passenger Presence System																																								
K	2013	Avalanche	Body	Radio																																								
K	2013	Avalanche	Body	Rear Heated Seat Module																																								
K	2013	Avalanche	Body	Rear HVAC/RSA																																								
K	2013	Avalanche	Body	Supplemental Inflatable Restraint																																								
K	2013	Avalanche	Body	Theft Deterrent Module																																								
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																								
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																								
K	2013	Cheyenne	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2013	Cheyenne	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																								
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2013	Cheyenne	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2013	Cheyenne	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
K	2013	Cheyenne	Chassis	EBCM Equal to or Over 8600 GVW without VSES																																								
K	2013	Cheyenne	Chassis	Electronic Suspension Control																																								
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																								
K	2013	Cheyenne	Chassis	FPCM with Trailer Brake Control																																								
K	2013	Cheyenne	Body	Amplifier (Bose)																																								
K	2013	Cheyenne	Body	Body Control Module																																								
K	2013	Cheyenne	Body	Body Control Module (aux.)																																								
K	2013	Cheyenne	Body	Digital Radio Receiver																																								
K	2013	Cheyenne	Body	Driver Door Switch																																								
K	2013	Cheyenne	Body	Instrument Panel Cluster																																								
K	2013	Cheyenne	Body	Park Assist Module																																								
K	2013	Cheyenne	Body	Passenger Door Switch																																								
K	2013	Cheyenne	Body	Passenger Presence System																																								
K	2013	Cheyenne	Body	Rear Heated Seat Module																																								
K	2013	Cheyenne	Body	Rear HVAC/RSA																																								
K	2013	Cheyenne	Body	Supplemental Inflatable Restraint																																								
K	2013	Cheyenne	Body	Theft Deterrent Module																																								
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																								
K	2013	Suburban	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																								
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2013	Suburban	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module 6 Speed																																								
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
K	2013	Suburban	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
K	2013	Suburban	Chassis	EBCM Under 8600 GVW																																								
K	2013	Suburban	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2013	Suburban	Chassis	Electronic Suspension Control																																								
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																								
K	2013	Suburban	Chassis	FPCM with Trailer Brake Control																																								
K	2013	Suburban	Body	Amplifier (Bose)																																								
K	2013	Suburban	Body	Assist Step Controller																																								
K	2013	Suburban	Body	Body Control Module																																								
K	2013	Suburban	Body	Body Control Module (aux.)																																								
K	2013	Suburban	Body	Digital Radio Receiver																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2013	Suburban	Body	Driver Door Switch																																								
K	2013	Suburban	Body	HVAC Control Module Auto																																								
K	2013	Suburban	Body	HVAC Control Module Manual																																								
K	2013	Suburban	Body	Instrument Panel Cluster																																								
K	2013	Suburban	Body	Left Side Object Detection Module																																								
K	2013	Suburban	Body	Lift Gate Module																																								
K	2013	Suburban	Body	Memory Seat Module																																								
K	2013	Suburban	Body	Navigation Radio																																								
K	2013	Suburban	Body	Park Assist Module																																								
K	2013	Suburban	Body	Passenger Door Switch																																								
K	2013	Suburban	Body	Passenger Presence System																																								
K	2013	Suburban	Body	Radio																																								
K	2013	Suburban	Body	Rear Heated Seat Module																																								
K	2013	Suburban	Body	Rear HVAC/RSA																																								
K	2013	Suburban	Body	Right Side Object Detection Module																																								
K	2013	Suburban	Body	Supplemental Inflatable Restraint																																								
K	2013	Suburban	Body	Theft Deterrent Module																																								
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Automatic																																								
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Engine Control Module Manual																																								
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2013	Silverado	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
K	2013	Silverado	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																								
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
K	2013	Silverado	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																								
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2013	Silverado	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Automatic																																								
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Engine Control Module Manual																																								
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
K	2013	Silverado	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																								
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
K	2013	Silverado	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																								
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2013	Silverado	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																								
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								
K	2013	Silverado	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																								
K	2013	Silverado	Chassis	EBCM Under 8600 GVW With VSES																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2013	Silverado	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW With VSES																																								
K	2013	Silverado	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
K	2013	Silverado	Chassis	Electronic Suspension Control																																								
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																								
K	2013	Silverado	Chassis	FPCM With Trailer Brake Control																																								
K	2013	Silverado	Body	Amplifier (Bose)																																								
K	2013	Silverado	Body	Body Control Module																																								
K	2013	Silverado	Body	Body Control Module (aux.)																																								
K	2013	Silverado	Body	Digital Radio Receiver																																								
K	2013	Silverado	Body	Driver Door Switch																																								
K	2013	Silverado	Body	HVAC Control Module Auto																																								
K	2013	Silverado	Body	HVAC Control Module Manual																																								
K	2013	Silverado	Body	Instrument Panel Cluster																																								
K	2013	Silverado	Body	Memory Seat Module																																								
K	2013	Silverado	Body	Navigation Radio																																								
K	2013	Silverado	Body	Park Assist Module																																								
K	2013	Silverado	Body	Passenger Door Switch																																								
K	2013	Silverado	Body	Passenger Presence System																																								
K	2013	Silverado	Body	Radio																																								
K	2013	Silverado	Body	Rear Heated Seat Module																																								
K	2013	Silverado	Body	Rear HVAC/RSA																																								
K	2013	Silverado	Body	Supplemental Inflatable Restraint																																								
K	2013	Silverado	Body	Theft Deterrent Module																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2013	Silverado Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2013	Silverado Hybrid	Chassis	Electronic Brake Control Module																																								
K	2013	Silverado Hybrid	Chassis	Electronic Suspension Control																																								
K	2013	Silverado Hybrid	Chassis	Power Steering Control Module																																								
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2013	Silverado Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2013	Silverado Hybrid	Body	A/C Compressor Control Module																																								
K	2013	Silverado Hybrid	Body	Amplifier (Bose)																																								
K	2013	Silverado Hybrid	Body	Body Control Module																																								
K	2013	Silverado Hybrid	Body	Body Control Module (aux.)																																								
K	2013	Silverado Hybrid	Body	Digital Radio Receiver																																								
K	2013	Silverado Hybrid	Body	Driver Door Switch																																								
K	2013	Silverado Hybrid	Body	Heated Seat Module																																								
K	2013	Silverado Hybrid	Body	HVAC Control Module																																								
K	2013	Silverado Hybrid	Body	Instrument Panel Cluster																																								
K	2013	Silverado Hybrid	Body	Navigation Radio																																								
K	2013	Silverado Hybrid	Body	Park Assist Module																																								
K	2013	Silverado Hybrid	Body	Passenger Door Switch																																								
K	2013	Silverado Hybrid	Body	Passenger Presence System																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2013	Silverado Hybrid	Body	Radio																																								
K	2013	Silverado Hybrid	Body	Rear Heated Seat Module																																								
K	2013	Silverado Hybrid	Body	Rear HVAC/RSA																																								
K	2013	Silverado Hybrid	Body	Serial Data Gateway Module																																								
K	2013	Silverado Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2013	Silverado Hybrid	Body	Theft Deterrent Module																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2013	Tahoe	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2013	Tahoe	Chassis	Electronic Brake Control Module																																								
K	2013	Tahoe	Chassis	Electronic Suspension Control																																								
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																								
K	2013	Tahoe	Chassis	FPCM with Trailer Brake Control																																								
K	2013	Tahoe	Body	Amplifier (Bose)																																								
K	2013	Tahoe	Body	Assist Step Controller																																								
K	2013	Tahoe	Body	Body Control Module																																								
K	2013	Tahoe	Body	Body Control Module (aux.)																																								
K	2013	Tahoe	Body	Digital Radio Receiver																																								
K	2013	Tahoe	Body	Driver Door Switch																																								
K	2013	Tahoe	Body	HVAC Control Module Auto																																								
K	2013	Tahoe	Body	HVAC Control Module Manual																																								
K	2013	Tahoe	Body	Instrument Panel Cluster																																								
K	2013	Tahoe	Body	Left Side Object Detection Module																																								
K	2013	Tahoe	Body	Lift Gate Module																																								
K	2013	Tahoe	Body	Memory Seat Module																																								
K	2013	Tahoe	Body	Navigation Radio																																								
K	2013	Tahoe	Body	Park Assist Module																																								
K	2013	Tahoe	Body	Passenger Door Switch																																								
K	2013	Tahoe	Body	Passenger Presence System																																								
K	2013	Tahoe	Body	Radio																																								
K	2013	Tahoe	Body	Rear Heated Seat Module																																								
K	2013	Tahoe	Body	Rear HVAC/RSA																																								
K	2013	Tahoe	Body	Right Side Object Detection Module																																								
K	2013	Tahoe	Body	Supplemental Inflatable Restraint																																								
K	2013	Tahoe	Body	Theft Deterrent Module																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 1																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Module 2																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2013	Tahoe Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2013	Tahoe Hybrid	Chassis	Electronic Brake Control Module																																								
K	2013	Tahoe Hybrid	Chassis	Electronic Suspension Control																																								
K	2013	Tahoe Hybrid	Chassis	Power Steering Control Module																																								
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2013	Tahoe Hybrid	Chassis	FPCM with Trailer Brake Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2013	Tahoe Hybrid	Body	A/C Compressor Control Module																																								
K	2013	Tahoe Hybrid	Body	Amplifier (Bose)																																								
K	2013	Tahoe Hybrid	Body	Body Control Module																																								
K	2013	Tahoe Hybrid	Body	Body Control Module (aux.)																																								
K	2013	Tahoe Hybrid	Body	Digital Radio Receiver																																								
K	2013	Tahoe Hybrid	Body	Driver Door Switch																																								
K	2013	Tahoe Hybrid	Body	Heated Seat Module																																								
K	2013	Tahoe Hybrid	Body	HVAC Control Module																																								
K	2013	Tahoe Hybrid	Body	Instrument Panel Cluster																																								
K	2013	Tahoe Hybrid	Body	Left Side Object Detection Module																																								
K	2013	Tahoe Hybrid	Body	Lift Gate Module																																								
K	2013	Tahoe Hybrid	Body	Navigation Radio																																								
K	2013	Tahoe Hybrid	Body	Park Assist Module																																								
K	2013	Tahoe Hybrid	Body	Passenger Door Switch																																								
K	2013	Tahoe Hybrid	Body	Passenger Presence System																																								
K	2013	Tahoe Hybrid	Body	Radio																																								
K	2013	Tahoe Hybrid	Body	Rear Heated Seat Module																																								
K	2013	Tahoe Hybrid	Body	Rear HVAC/RSA																																								
K	2013	Tahoe Hybrid	Body	Right Side Object Detection Module																																								
K	2013	Tahoe Hybrid	Body	Serial Data Gateway Module																																								
K	2013	Tahoe Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2013	Tahoe Hybrid	Body	Theft Deterrent Module																																								
K	2014	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
K	2014	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																								
K	2014	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																								
K	2014	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																								
K	2014	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
K	2014	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
K	2014	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																								
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
K	2014	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
K	2014	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
K	2014	Cheyenne	Chassis	Electronic Brake Control Module																																								
K	2014	Cheyenne	Chassis	Parking Brake Control Module																																								
K	2014	Cheyenne	Chassis	Power Steering Control Module																																								
K	2014	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																								
K	2014	Cheyenne	Body	Body Control Module																																								
K	2014	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
K	2014	Cheyenne	Body	Passenger Presence Module																																								
K	2014	Cheyenne	Body	Instrument Cluster																																								
K	2014	Cheyenne	Body	Radio Control																																								
K	2014	Cheyenne	Body	HVAC Control																																								
K	2014	Cheyenne	Body	Radio																																								
K	2014	Cheyenne	Body	Amplifier																																								
K	2014	Cheyenne	Body	Media Disc Player																																								
K	2014	Cheyenne	Body	Human Machine Interface Control Module																																								
K	2014	Cheyenne	Body	Telematics Communication Interface Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2014	Cheyenne	Body	HVAC Control Module																																								
K	2014	Cheyenne	Body	Left Side Object Detection Control Module																																								
K	2014	Cheyenne	Body	Parking Assist Control Module																																								
K	2014	Cheyenne	Body	Frontview Camera Module																																								
K	2014	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
K	2014	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
K	2014	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																								
K	2014	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
K	2014	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																								
K	2014	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
K	2014	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																								
K	2014	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
K	2014	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
K	2014	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																								
K	2014	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
K	2014	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
K	2014	Silverado	Chassis	Electronic Brake Control Module																																								
K	2014	Silverado	Chassis	Parking Brake Control Module																																								
K	2014	Silverado	Chassis	Power Steering Control Module																																								
K	2014	Silverado	Chassis	Steering Wheel Angle Sensor Module																																								
K	2014	Silverado	Body	Body Control Module																																								
K	2014	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
K	2014	Silverado	Body	Passenger Presence Module																																								
K	2014	Silverado	Body	Instrument Cluster																																								
K	2014	Silverado	Body	Radio Control																																								
K	2014	Silverado	Body	HVAC Control																																								
K	2014	Silverado	Body	Radio																																								
K	2014	Silverado	Body	Amplifier																																								
K	2014	Silverado	Body	Media Disc Player																																								
K	2014	Silverado	Body	Human Machine Interface Control Module																																								
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 9																																								
K	2014	Silverado	Body	Telematics Communication Interface Control Module Version 10																																								
K	2014	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																								
K	2014	Silverado	Body	HVAC Manual Control Heater Only (C42)																																								
K	2014	Silverado	Body	HVAC Manual Control Single Zone (C67)																																								
K	2014	Silverado	Body	Parking Assist Control Module																																								
K	2014	Silverado	Body	Frontview Camera Module																																								
K	2014	Silverado HD	Powertrain	5.3L LFT Transmission Control Module																																								
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Engine Control Module																																								
K	2014	Silverado HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																								
K	2014	Silverado HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Engine Control Module																																								
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																								
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Transmission Control Module																																								
K	2014	Silverado HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
K	2014	Silverado HD	Powertrain	Transfer Case Control Module																																								
K	2014	Silverado HD	Chassis	Electronic Brake Control Module																																								
K	2014	Silverado HD	Chassis	Trailer Brake Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2014	Silverado HD	Chassis	Suspension Control Module																																								
K	2014	Silverado HD	Body	Body Control Module																																								
K	2014	Silverado HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
K	2014	Silverado HD	Body	Passenger Presence Module																																								
K	2014	Silverado HD	Body	Instrument Cluster																																								
K	2014	Silverado HD	Body	Chime Alarm Control Module																																								
K	2014	Silverado HD	Body	Base Radio																																								
K	2014	Silverado HD	Body	Navigation Radio																																								
K	2014	Silverado HD	Body	Uplevel Radio																																								
K	2014	Silverado HD	Body	Amplifier																																								
K	2014	Silverado HD	Body	Rear Audio Control Module																																								
K	2014	Silverado HD	Body	Digital Radio Receiver Control Module																																								
K	2014	Silverado HD	Body	Personal Audio Link Control Module																																								
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 9																																								
K	2014	Silverado HD	Body	Telematics Communication Interface Control Module Version 10																																								
K	2014	Silverado HD	Body	HVAC Auto Control Dual Zone (CJ2)																																								
K	2014	Silverado HD	Body	HVAC Manual Control Heater Only (C42)																																								
K	2014	Silverado HD	Body	HVAC Manual Control Dual Zone (CJ3)																																								
K	2014	Silverado HD	Body	HVAC Manual Control Single Zone (C67)																																								
K	2014	Silverado HD	Body	Driver Door Switch Panel Control Module																																								
K	2014	Silverado HD	Body	Passenger Door Switch Panel Control Module																																								
K	2014	Silverado HD	Body	Seat Memory Control Module																																								
K	2014	Silverado HD	Body	Remote Control Door Lock Receiver																																								
K	2014	Silverado HD	Body	Parking Assist Control Module																																								
K	2014	Silverado HD	Body	Theft Deterrent Module																																								
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Engine Control Module																																								
K	2014	Suburban	Powertrain	(7) 5.3L LC9 Transmission Control Module																																								
K	2014	Suburban	Powertrain	(0) 5.3L LMG Engine Control Module																																								
K	2014	Suburban	Powertrain	(0) 5.3L LMG Transmission Control Module																																								
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump																																								
K	2014	Suburban	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																								
K	2014	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																								
K	2014	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
K	2014	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
K	2014	Suburban	Chassis	Electronic Brake Control Module																																								
K	2014	Suburban	Chassis	Parking Brake Control Module																																								
K	2014	Suburban	Chassis	Suspension Control Module																																								
K	2014	Suburban	Body	Body Control Module																																								
K	2014	Suburban	Body	Auxiliary Body Control Module																																								
K	2014	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
K	2014	Suburban	Body	Passenger Presence Module																																								
K	2014	Suburban	Body	Instrument Cluster																																								
K	2014	Suburban	Body	Base Radio																																								
K	2014	Suburban	Body	Navigation Radio																																								
K	2014	Suburban	Body	Uplevel Radio																																								
K	2014	Suburban	Body	Amplifier																																								
K	2014	Suburban	Body	Rear Audio Control Module																																								
K	2014	Suburban	Body	Digital Radio Receiver Control Module																																								
K	2014	Suburban	Body	Personal Audio Link Control Module																																								
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 9																																								
K	2014	Suburban	Body	Telematics Communication Interface Control Module Version 10																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2014	Suburban	Body	HVAC Auto Control Dual Zone (CJ2)																																								
K	2014	Suburban	Body	HVAC Manual Control Dual Zone (CJ3)																																								
K	2014	Suburban	Body	Driver Door Switch Panel Control Module																																								
K	2014	Suburban	Body	Passenger Door Switch Panel Control Module																																								
K	2014	Suburban	Body	Liftgate Control Module																																								
K	2014	Suburban	Body	Seat Memory Control Module																																								
K	2014	Suburban	Body	Rear Seat Heating Control Module																																								
K	2014	Suburban	Body	Assist Step Control Module																																								
K	2014	Suburban	Body	Right Side Object Detection Control Module																																								
K	2014	Suburban	Body	Left Side Object Detection Control Module																																								
K	2014	Suburban	Body	Remote Control Door Lock Receiver																																								
K	2014	Suburban	Body	Parking Assist Control Module																																								
K	2014	Suburban	Body	Theft Deterrent Module																																								
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Engine Control Module																																								
K	2014	Tahoe	Powertrain	(0) 5.3L LMG Transmission Control Module																																								
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump																																								
K	2014	Tahoe	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																								
K	2014	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
K	2014	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
K	2014	Tahoe	Chassis	Electronic Brake Control Module																																								
K	2014	Tahoe	Chassis	Parking Brake Control Module																																								
K	2014	Tahoe	Chassis	Suspension Control Module																																								
K	2014	Tahoe	Body	Body Control Module																																								
K	2014	Tahoe	Body	Auxiliary Body Control Module																																								
K	2014	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
K	2014	Tahoe	Body	Passenger Presence Module																																								
K	2014	Tahoe	Body	Instrument Cluster																																								
K	2014	Tahoe	Body	Base Radio																																								
K	2014	Tahoe	Body	Navigation Radio																																								
K	2014	Tahoe	Body	Uplevel Radio																																								
K	2014	Tahoe	Body	Amplifier																																								
K	2014	Tahoe	Body	Rear Audio Control Module																																								
K	2014	Tahoe	Body	Digital Radio Receiver Control Module																																								
K	2014	Tahoe	Body	Personal Audio Link Control Module																																								
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 9																																								
K	2014	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																								
K	2014	Tahoe	Body	HVAC Auto Control Dual Zone (CJ2)																																								
K	2014	Tahoe	Body	HVAC Manual Control Dual Zone (CJ3)																																								
K	2014	Tahoe	Body	Driver Door Switch Panel Control Module																																								
K	2014	Tahoe	Body	Passenger Door Switch Panel Control Module																																								
K	2014	Tahoe	Body	Liftgate Control Module																																								
K	2014	Tahoe	Body	Seat Memory Control Module																																								
K	2014	Tahoe	Body	Rear Seat Heating Control Module																																								
K	2014	Tahoe	Body	Assist Step Control Module																																								
K	2014	Tahoe	Body	Right Side Object Detection Control Module																																								
K	2014	Tahoe	Body	Left Side Object Detection Control Module																																								
K	2014	Tahoe	Body	Remote Control Door Lock Receiver																																								
K	2014	Tahoe	Body	Parking Assist Control Module																																								
K	2014	Tahoe	Body	Theft Deterrent Module																																								
K	2015	Cheyenne	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2015	Cheyenne	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																								
K	2015	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Engine Control Module																																								
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Fuel Injector Control Module																																								
K	2015	Cheyenne	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																								
K	2015	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
K	2015	Cheyenne	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
K	2015	Cheyenne	Powertrain	Chassis Control Version Trailer Brake Control																																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Wheel Drive																																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
K	2015	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
K	2015	Cheyenne	Chassis	Electronic Brake Control Module																																								
K	2015	Cheyenne	Chassis	Power Steering Control Module																																								
K	2015	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																								
K	2015	Cheyenne	Chassis	Suspension Control Module																																								
K	2015	Cheyenne	Body	Body Control Module																																								
K	2015	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
K	2015	Cheyenne	Body	Passenger Presence Module																																								
K	2015	Cheyenne	Body	Instrument Cluster																																								
K	2015	Cheyenne	Body	Radio Controls																																								
K	2015	Cheyenne	Body	HVAC Controls																																								
K	2015	Cheyenne	Body	Radio																																								
K	2015	Cheyenne	Body	Amplifier																																								
K	2015	Cheyenne	Body	Media Disc Player																																								
K	2015	Cheyenne	Body	Human Machine Interface Control Module																																								
K	2015	Cheyenne	Body	Telematics Communication Interface Control Module																																								
K	2015	Cheyenne	Body	HVAC Control Module																																								
K	2015	Cheyenne	Body	Parking Assist Control Module																																								
K	2015	Cheyenne	Body	Frontview Camera Module																																								
K	2015	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
K	2015	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
K	2015	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																								
K	2015	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
K	2015	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																								
K	2015	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																								
K	2015	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
K	2015	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																								
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
K	2015	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
K	2015	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																								
K	2015	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																								
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																								
K	2015	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																								
K	2015	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2015	Silverado	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
K	2015	Silverado	Powertrain	Chassis Control Version Trailer Brake Control																																								
K	2015	Silverado	Powertrain	Transfer Case Version Two Wheel Drive																																								
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																								
K	2015	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
K	2015	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
K	2015	Silverado	Chassis	Electronic Brake Control Module																																								
K	2015	Silverado	Chassis	Distance Sensing Cruise Control Module																																								
K	2015	Silverado	Chassis	Power Steering Control Module																																								
K	2015	Silverado	Chassis	Steering Wheel Angle Sensor Module																																								
K	2015	Silverado	Chassis	Suspension Control Module																																								
K	2015	Silverado	Body	Body Control Module																																								
K	2015	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
K	2015	Silverado	Body	Passenger Presence Module																																								
K	2015	Silverado	Body	Instrument Cluster																																								
K	2015	Silverado	Body	Radio Controls																																								
K	2015	Silverado	Body	HVAC Controls																																								
K	2015	Silverado	Body	Radio																																								
K	2015	Silverado	Body	Amplifier																																								
K	2015	Silverado	Body	Media Disc Player																																								
K	2015	Silverado	Body	Human Machine Interface Control Module																																								
K	2015	Silverado	Body	Telematics Communication Interface Control Module																																								
K	2015	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																								
K	2015	Silverado	Body	HVAC Manual Control Heater Only (C42)																																								
K	2015	Silverado	Body	HVAC Manual Control Single Zone (C67)																																								
K	2015	Silverado	Body	Parking Assist Control Module																																								
K	2015	Silverado	Body	Frontview Camera Module																																								
K	2015	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																								
K	2015	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
K	2015	Suburban	Powertrain	(J) 6.2L L86 Engine Control Module																																								
K	2015	Suburban	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
K	2015	Suburban	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control																																								
K	2015	Suburban	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																								
K	2015	Suburban	Powertrain	Transfer Case Version Two Wheel Drive																																								
K	2015	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
K	2015	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
K	2015	Suburban	Chassis	Electronic Brake Control Module																																								
K	2015	Suburban	Chassis	Distance Sensing Cruise Control Module																																								
K	2015	Suburban	Chassis	Parking Brake Control Module																																								
K	2015	Suburban	Chassis	Multi-Axis Acceleration Sensor Module																																								
K	2015	Suburban	Chassis	Power Steering Control Module																																								
K	2015	Suburban	Chassis	Steering Wheel Angle Sensor Module																																								
K	2015	Suburban	Chassis	Suspension Control Module																																								
K	2015	Suburban	Body	Body Control Module																																								
K	2015	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
K	2015	Suburban	Body	Passenger Presence Module																																								
K	2015	Suburban	Body	Instrument Cluster																																								
K	2015	Suburban	Body	Radio Controls																																								
K	2015	Suburban	Body	HVAC Controls																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2015	Suburban	Body	Radio																																								
K	2015	Suburban	Body	Amplifier																																								
K	2015	Suburban	Body	Media Disc Player																																								
K	2015	Suburban	Body	Human Machine Interface Control Module																																								
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.6																																								
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 9.7																																								
K	2015	Suburban	Body	Telematics Communication Interface Control Module Version 10																																								
K	2015	Suburban	Body	HVAC Control Module																																								
K	2015	Suburban	Body	Liftgate Control Module																																								
K	2015	Suburban	Body	Keyless Entry Control Module																																								
K	2015	Suburban	Body	Assist Step Control Module																																								
K	2015	Suburban	Body	Left Side Object Detection Control Module																																								
K	2015	Suburban	Body	Parking Assist Control Module																																								
K	2015	Suburban	Body	Frontview Camera Module																																								
K	2015	Suburban	Body	Steering Column Lock Control Module																																								
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																								
K	2015	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Engine Control Module																																								
K	2015	Tahoe	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
K	2015	Tahoe	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control																																								
K	2015	Tahoe	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																								
K	2015	Tahoe	Powertrain	Transfer Case Version Two Wheel Drive																																								
K	2015	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
K	2015	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
K	2015	Tahoe	Powertrain	Drive Motor Control Module 1																																								
K	2015	Tahoe	Powertrain	Drive Motor Control Module 2																																								
K	2015	Tahoe	Powertrain	Auxiliary Transmission Fluid Pump																																								
K	2015	Tahoe	Chassis	Electronic Brake Control Module																																								
K	2015	Tahoe	Chassis	Distance Sensing Cruise Control Module																																								
K	2015	Tahoe	Chassis	Parking Brake Control Module																																								
K	2015	Tahoe	Chassis	Multi-Axis Acceleration Sensor Module																																								
K	2015	Tahoe	Chassis	Power Steering Control Module																																								
K	2015	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																								
K	2015	Tahoe	Chassis	Suspension Control Module																																								
K	2015	Tahoe	Body	Body Control Module																																								
K	2015	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
K	2015	Tahoe	Body	Passenger Presence Module																																								
K	2015	Tahoe	Body	Instrument Cluster																																								
K	2015	Tahoe	Body	Radio Controls																																								
K	2015	Tahoe	Body	HVAC Controls																																								
K	2015	Tahoe	Body	Radio																																								
K	2015	Tahoe	Body	Amplifier																																								
K	2015	Tahoe	Body	Media Disc Player																																								
K	2015	Tahoe	Body	Human Machine Interface Control Module																																								
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.6																																								
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 9.7																																								
K	2015	Tahoe	Body	Telematics Communication Interface Control Module Version 10																																								
K	2015	Tahoe	Body	HVAC Control Module																																								
K	2015	Tahoe	Body	Liftgate Control Module																																								
K	2015	Tahoe	Body	Keyless Entry Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2015	Tahoe	Body	Assist Step Control Module																																								
K	2015	Tahoe	Body	Left Side Object Detection Control Module																																								
K	2015	Tahoe	Body	Parking Assist Control Module																																								
K	2015	Tahoe	Body	Frontview Camera Module																																								
K	2015	Tahoe	Body	Steering Column Lock Control Module																																								
K	2015	Tahoe	Body	Battery Energy Control Module																																								
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Engine Control Module																																								
K	2016	Cheyenne	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Engine Control Module																																								
K	2016	Cheyenne	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
K	2016	Cheyenne	Powertrain	Fuel Injector Control Module																																								
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																								
K	2016	Cheyenne	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
K	2016	Cheyenne	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
K	2016	Cheyenne	Chassis	Electronic Brake Control Module																																								
K	2016	Cheyenne	Chassis	Power Steering Control Module																																								
K	2016	Cheyenne	Chassis	Steering Wheel Angle Sensor Module																																								
K	2016	Cheyenne	Chassis	Suspension Control Module																																								
K	2016	Cheyenne	Body	Body Control Module																																								
K	2016	Cheyenne	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
K	2016	Cheyenne	Body	Passenger Presence Module																																								
K	2016	Cheyenne	Body	Instrument Cluster																																								
K	2016	Cheyenne	Body	Radio Controls																																								
K	2016	Cheyenne	Body	HVAC Controls																																								
K	2016	Cheyenne	Body	Radio																																								
K	2016	Cheyenne	Body	Amplifier																																								
K	2016	Cheyenne	Body	Media Disc Player																																								
K	2016	Cheyenne	Body	Human Machine Interface Control Module																																								
K	2016	Cheyenne	Body	Telematics Communication Interface Control Module																																								
K	2016	Cheyenne	Body	HVAC Control Module																																								
K	2016	Cheyenne	Body	Assist Step Object Detection Control Module																																								
K	2016	Cheyenne	Body	Parking Assist Control Module																																								
K	2016	Cheyenne	Body	Frontview Camera Module																																								
K	2016	Cheyenne	Body	Frontview Camera Module																																								
K	2016	Silverado	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
K	2016	Silverado	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
K	2016	Silverado	Powertrain	(C) 5.3L L83 Engine Control Module																																								
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																								
K	2016	Silverado	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																								
K	2016	Silverado	Powertrain	(R) 5.3L L8B Engine Control Module																																								
K	2016	Silverado	Powertrain	(R) 5.3L L8B Transmission Control Module																																								
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																								
K	2016	Silverado	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																								
K	2016	Silverado	Powertrain	(G) 6.0L L96 Engine Control Module																																								
K	2016	Silverado	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																								
K	2016	Silverado	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
K	2016	Silverado	Powertrain	(J) 6.2L L86 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
K	2016	Silverado	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
K	2016	Silverado	Powertrain	(8) 6.6L LML Engine Control Module																																								
K	2016	Silverado	Powertrain	(8) 6.6L LML Glow Plug Control Module																																								
K	2016	Silverado	Powertrain	(8) 6.6L LML Transmission Control Module																																								
K	2016	Silverado	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																								
K	2016	Silverado	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
K	2016	Silverado	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
K	2016	Silverado	Chassis	Electronic Brake Control Module																																								
K	2016	Silverado	Chassis	Power Steering Control Module																																								
K	2016	Silverado	Chassis	Power Steering Control Module																																								
K	2016	Silverado	Chassis	Steering Wheel Angle Sensor Module																																								
K	2016	Silverado	Chassis	Suspension Control Module																																								
K	2016	Silverado	Body	Body Control Module																																								
K	2016	Silverado	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
K	2016	Silverado	Body	Passenger Presence Module																																								
K	2016	Silverado	Body	Instrument Cluster																																								
K	2016	Silverado	Body	Radio Controls																																								
K	2016	Silverado	Body	HVAC Controls																																								
K	2016	Silverado	Body	Radio (IO3)																																								
K	2016	Silverado	Body	Radio (IOB)																																								
K	2016	Silverado	Body	Uplevel Radio (IO4 IO5 IO6)																																								
K	2016	Silverado	Body	Amplifier																																								
K	2016	Silverado	Body	Media Disc Player																																								
K	2016	Silverado	Body	Human Machine Interface Control Module																																								
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 9.7																																								
K	2016	Silverado	Body	Telematics Communication Interface Control Module Version 10																																								
K	2016	Silverado	Body	HVAC Auto Control Dual Zone (CJ2)																																								
K	2016	Silverado	Body	HVAC Manual Control Heater Only (C42)																																								
K	2016	Silverado	Body	HVAC Manual Control Single Zone (C67)																																								
K	2016	Silverado	Body	Seat Memory Control Module - Driver																																								
K	2016	Silverado	Body	Assist Step Object Detection Control Module																																								
K	2016	Silverado	Body	Parking Assist Control Module																																								
K	2016	Silverado	Body	Frontview Camera Module																																								
K	2016	Silverado	Body	Frontview Camera Module																																								
K	2016	Suburban	Powertrain	(C) 5.3L L83 Engine Control Module																																								
K	2016	Suburban	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
K	2016	Suburban	Powertrain	(G) 6.0L L96 Engine Control Module																																								
K	2016	Suburban	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
K	2016	Suburban	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
K	2016	Suburban	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
K	2016	Suburban	Chassis	Electronic Brake Control Module																																								
K	2016	Suburban	Chassis	Distance Sensing Cruise Control Module																																								
K	2016	Suburban	Chassis	Parking Brake Control Module																																								
K	2016	Suburban	Chassis	Power Steering Control Module																																								
K	2016	Suburban	Chassis	Steering Wheel Angle Sensor Module																																								
K	2016	Suburban	Chassis	Suspension Control Module																																								
K	2016	Suburban	Body	Body Control Module																																								
K	2016	Suburban	Body	Inflatable Restraint Sensing and Diagnostic Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2016	Suburban	Body	Passenger Presence Module																																								
K	2016	Suburban	Body	Instrument Cluster																																								
K	2016	Suburban	Body	Radio Controls																																								
K	2016	Suburban	Body	HVAC Controls																																								
K	2016	Suburban	Body	Radio																																								
K	2016	Suburban	Body	Amplifier																																								
K	2016	Suburban	Body	Media Disc Player																																								
K	2016	Suburban	Body	Human Machine Interface Control Module																																								
K	2016	Suburban	Body	Telematics Communication Interface Control Module																																								
K	2016	Suburban	Body	HVAC Control Module																																								
K	2016	Suburban	Body	Liftgate Control Module																																								
K	2016	Suburban	Body	Seat Memory Control Module - Passenger																																								
K	2016	Suburban	Body	Seat Memory Control Module - Driver																																								
K	2016	Suburban	Body	Keyless Entry Control Module																																								
K	2016	Suburban	Body	Assist Step Control Module																																								
K	2016	Suburban	Body	Left Side Object Detection Control Module																																								
K	2016	Suburban	Body	Parking Assist Control Module																																								
K	2016	Suburban	Body	Frontview Camera Module																																								
K	2016	Suburban	Body	Steering Column Lock Control Module																																								
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Engine Control Module																																								
K	2016	Tahoe	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
K	2016	Tahoe	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
K	2016	Tahoe	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
K	2016	Tahoe	Chassis	Electronic Brake Control Module																																								
K	2016	Tahoe	Chassis	Distance Sensing Cruise Control Module																																								
K	2016	Tahoe	Chassis	Parking Brake Control Module																																								
K	2016	Tahoe	Chassis	Power Steering Control Module																																								
K	2016	Tahoe	Chassis	Steering Wheel Angle Sensor Module																																								
K	2016	Tahoe	Chassis	Suspension Control Module																																								
K	2016	Tahoe	Body	Body Control Module																																								
K	2016	Tahoe	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
K	2016	Tahoe	Body	Passenger Presence Module																																								
K	2016	Tahoe	Body	Instrument Cluster																																								
K	2016	Tahoe	Body	Radio Controls																																								
K	2016	Tahoe	Body	HVAC Controls																																								
K	2016	Tahoe	Body	Radio																																								
K	2016	Tahoe	Body	Amplifier																																								
K	2016	Tahoe	Body	Media Disc Player																																								
K	2016	Tahoe	Body	Human Machine Interface Control Module																																								
K	2016	Tahoe	Body	Telematics Communication Interface Control Module																																								
K	2016	Tahoe	Body	HVAC Control Module																																								
K	2016	Tahoe	Body	Liftgate Control Module																																								
K	2016	Tahoe	Body	Seat Memory Control Module - Passenger																																								
K	2016	Tahoe	Body	Seat Memory Control Module - Driver																																								
K	2016	Tahoe	Body	Keyless Entry Control Module																																								
K	2016	Tahoe	Body	Assist Step Control Module																																								
K	2016	Tahoe	Body	Left Side Object Detection Control Module																																								
K	2016	Tahoe	Body	Parking Assist Control Module																																								
K	2016	Tahoe	Body	Frontview Camera Module																																								
K	2016	Tahoe	Body	Steering Column Lock Control Module																																								
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																								
L	2004	ALL	Chassis	4WAL 3 Sensor																																								
L	2004	ALL	Body	Body Control Module																																								
L	2004	ALL	Body	Instrument Panel Cluster																																								
L	2004	ALL	Body	Supplemental Inflatable Restraint																																								
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
L	2005	Astro	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																								
L	2005	Astro	Chassis	4WAL 3 Sensor																																								
L	2005	Astro	Body	Body Control Module																																								
L	2005	Astro	Body	Instrument Panel Cluster																																								
L	2005	Astro	Body	Supplemental Inflatable Restraint																																								
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																								
L	2005	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																								
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control Yes																																								
L	2005	Equinox	Chassis	Anti-lock Brake System Traction Control No																																								
L	2005	Equinox	Chassis	Electric Power Steering																																								
L	2005	Equinox	Body	Body Control Module																																								
L	2005	Equinox	Body	Instrument Panel Cluster																																								
L	2005	Equinox	Body	Radio																																								
L	2005	Equinox	Body	Supplemental Inflatable Restraint																																								
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																								
L	2006	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module																																								
L	2006	ALL	Chassis	Traction Control Yes																																								
L	2006	ALL	Chassis	Traction Control No																																								
L	2006	ALL	Chassis	Electric Power Steering																																								
L	2006	ALL	Body	Body Control Module	V																																							
L	2006	ALL	Body	Instrument Panel Cluster																																								
L	2006	ALL	Body	Radio																																								
L	2006	ALL	Body	Supplemental Inflatable Restraint																																								
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																								
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Transmission Control Module		V																																						
L	2007	ALL	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																								
L	2007	ALL	Chassis	Electronic Brake Control Module with Traction Control																																								
L	2007	ALL	Chassis	Electronic Brake Control Module without Traction Control																																								
L	2007	ALL	Chassis	Power Steering Control Module																																								
L	2007	ALL	Body	Body Control Module																																								
L	2007	ALL	Body	Digital Radio Receiver																																								
L	2007	ALL	Body	Heated Seat Module																																								
L	2007	ALL	Body	HVAC Control Module																																								
L	2007	ALL	Body	Instrument Panel Cluster																																								
L	2007	ALL	Body	Passenger Presence System																																								
L	2007	ALL	Body	Radio																																								
L	2007	ALL	Body	Rollover Sensor																																								
L	2007	ALL	Body	Supplemental Inflatable Restraint																																								
L	2007	ALL	Body	Theft Deterrent Module																																								
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																								
L	2008	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																								
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2008	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																								
L	2008	Captiva Sport	Chassis	Electronic Brake Control Module																																								
L	2008	Captiva Sport	Body	Body Control Module																																								
L	2008	Captiva Sport	Body	Digital Radio Receiver																																								
L	2008	Captiva Sport	Body	HVAC Control Module Auto			V																																					
L	2008	Captiva Sport	Body	HVAC Control Module Manual																																								
L	2008	Captiva Sport	Body	Instrument Panel Cluster																																								
L	2008	Captiva Sport	Body	Passenger Presence System																																								
L	2008	Captiva Sport	Body	Radio																																								
L	2008	Captiva Sport	Body	Remote Control Door Lock Receiver																																								
L	2008	Captiva Sport	Body	Rollover Sensor																																								
L	2008	Captiva Sport	Body	Supplemental Inflatable Restraint																																								
L	2008	Captiva Sport	Body	Theft Deterrent Module																																								
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																								
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																								
L	2008	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module		V																																						
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																								
L	2008	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																								
L	2008	Equinox	Chassis	Electronic Brake Control Module																																								
L	2008	Equinox	Chassis	Power Steering Control Module																																								
L	2008	Equinox	Body	Body Control Module																																								
L	2008	Equinox	Body	Digital Radio Receiver																																								
L	2008	Equinox	Body	Heated Seat Module																																								
L	2008	Equinox	Body	HVAC Control Module																																								
L	2008	Equinox	Body	Instrument Panel Cluster																																								
L	2008	Equinox	Body	Passenger Presence System																																								
L	2008	Equinox	Body	Radio																																								
L	2008	Equinox	Body	Rollover Sensor																																								
L	2008	Equinox	Body	Supplemental Inflatable Restraint																																								
L	2008	Equinox	Body	Theft Deterrent Module																																								
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Engine Control Module																																								
L	2009	Captiva Sport	Powertrain	(P)2.4L L4 LE5 Transmission Control Module																																								
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																								
L	2009	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																								
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																								
L	2009	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																								
L	2009	Captiva Sport	Chassis	Electronic Brake Control Module																																								
L	2009	Captiva Sport	Chassis	Power Steering Control Module																																								
L	2009	Captiva Sport	Body	Body Control Module																																								
L	2009	Captiva Sport	Body	HVAC Control Module Auto			V																																					
L	2009	Captiva Sport	Body	HVAC Control Module Manual																																								
L	2009	Captiva Sport	Body	Instrument Panel Cluster																																								
L	2009	Captiva Sport	Body	Passenger Presence System																																								
L	2009	Captiva Sport	Body	Radio																																								
L	2009	Captiva Sport	Body	Remote Control Door Lock Receiver																																								
L	2009	Captiva Sport	Body	Rollover Sensor																																								
L	2009	Captiva Sport	Body	Supplemental Inflatable Restraint																																								
L	2009	Captiva Sport	Body	Theft Deterrent Module																																								
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Rear Drive System																																								
L	2009	Equinox	Powertrain	(F)3.4L V6 LNJ Transmission Control Module		V																																						
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																								
L	2009	Equinox	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																								
L	2009	Equinox	Chassis	Electronic Brake Control Module																																								
L	2009	Equinox	Chassis	Power Steering Control Module																																								
L	2009	Equinox	Body	Body Control Module																																								
L	2009	Equinox	Body	Digital Radio Receiver																																								
L	2009	Equinox	Body	Heated Seat Module																																								
L	2009	Equinox	Body	HVAC Control Module																																								
L	2009	Equinox	Body	Instrument Panel Cluster																																								
L	2009	Equinox	Body	Passenger Presence System																																								
L	2009	Equinox	Body	Radio																																								
L	2009	Equinox	Body	Rollover Sensor																																								
L	2009	Equinox	Body	Supplemental Inflatable Restraint																																								
L	2009	Equinox	Body	Theft Deterrent Module																																								
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																								
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Fuel Pump Control Module																																								
L	2010	Captiva Sport	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																								
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Engine Control Module																																								
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Fuel Pump Control Module																																								
L	2010	Captiva Sport	Powertrain	(V)2.4L L4 LE9 Transmission Control Module																																								
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Engine Control Module																																								
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Fuel Pump Control Module																																								
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Rear Drive System																																								
L	2010	Captiva Sport	Powertrain	(7)3.6L V6 LY7 Transmission Control Module																																								
L	2010	Captiva Sport	Chassis	Electronic Brake Control Module																																								
L	2010	Captiva Sport	Chassis	Power Steering Control Module																																								
L	2010	Captiva Sport	Body	Body Control Module																																								
L	2010	Captiva Sport	Body	HVAC Control Module			V																																					
L	2010	Captiva Sport	Body	Instrument Panel Cluster																																								
L	2010	Captiva Sport	Body	Passenger Presence System																																								
L	2010	Captiva Sport	Body	Radio																																								
L	2010	Captiva Sport	Body	Remote Control Door Lock Receiver																																								
L	2010	Captiva Sport	Body	Rollover Sensor																																								
L	2010	Captiva Sport	Body	Supplemental Inflatable Restraint																																								
L	2010	Captiva Sport	Body	Theft Deterrent Module																																								
L	2010	Equinox	Powertrain	(W) 2.4L LAF Engine Control Module																																								
L	2010	Equinox	Powertrain	(W) 2.4L LAF Transmission Control Module																																								
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Engine Control Module																																								
L	2010	Equinox	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																								
L	2010	Equinox	Powertrain	Fuel Pump Control Module																																								
L	2010	Equinox	Powertrain	Rear Differential Clutch Control Module																																								
L	2010	Equinox	Chassis	Electronic Brake Control Module																																								
L	2010	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2010	Equinox	Chassis	Steering Wheel Angle Sensor Module																																								
L	2010	Equinox	Body	Body Control Module																																								
L	2010	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2010	Equinox	Body	Passenger Presence Module																																								
L	2010	Equinox	Body	Instrument Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2010	Equinox	Body	Radio																																								
L	2010	Equinox	Body	Multimedia Player Interface Module																																								
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 9																																								
L	2010	Equinox	Body	Telematics Communication Interface Control Module Version 10																																								
L	2010	Equinox	Body	HVAC Control Module Auto Single (C68)																																								
L	2010	Equinox	Body	HVAC Control Module Manual Single (C67)																																								
L	2010	Equinox	Body	Liftgate Control Module																																								
L	2010	Equinox	Body	Parking Assist Control Module																																								
L	2010	Equinox	Body	Frontview Camera Module																																								
L	2010	Equinox	Body	Vehicle Direction Camera Control Module																																								
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
L	2011	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
L	2011	Captiva	Powertrain	2.0L LNP Transmission Control Module																																								
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Automatic Transmission																																								
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Engine Control Module Manual Transmission																																								
L	2011	Captiva	Powertrain	(H) 2.2L LNQ Transmission Control Module																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Automatic Transmission																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Engine Control Module Manual Transmission																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Fuel Pump Control Module																																								
L	2011	Captiva	Powertrain	(1) 2.4L LE5 Transmission Control Module																																								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Automatic Transmission																																								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Engine Control Module Manual Transmission																																								
L	2011	Captiva	Powertrain	(U) 2.4L LE9 Transmission Control Module																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Automatic Transmission																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Engine Control Module Manual Transmission																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Fuel Pump Control Module																																								
L	2011	Captiva	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																								
L	2011	Captiva	Powertrain	Rear Differential Clutch Control Module																																								
L	2011	Captiva	Chassis	Electronic Brake Control Module																																								
L	2011	Captiva	Chassis	Parking Brake Control Module																																								
L	2011	Captiva	Body	Body Control Module																																								
L	2011	Captiva	Body	Auxiliary Body Control Module																																								
L	2011	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2011	Captiva	Body	Instrument Cluster																																								
L	2011	Captiva	Body	Headlamp Control Module																																								
L	2011	Captiva	Body	HVAC Control Module																																								
L	2011	Captiva	Body	Remote Control Door Lock Receiver																																								
L	2011	Captiva	Body	Parking Assist Control Module																																								
L	2011	Captiva	Body	Theft Deterrent Module																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Engine Control Module																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Fuel Pump Control Module																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Rear Drive System																																								
L	2011	Captiva Sport	Powertrain	(W)2.4L L4 LAF Transmission Control Module																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Engine Control Module																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Fuel Pump Control Module																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Rear Drive System																																								
L	2011	Captiva Sport	Powertrain	(Y)3.0L V6 LF1 Transmission Control Module																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																								
L	2011	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2011	Captiva Sport	Chassis	Electronic Brake Control Module																																								
L	2011	Captiva Sport	Chassis	Parking Brake Control Module																																								
L	2011	Captiva Sport	Body	Body Control Module																																								
L	2011	Captiva Sport	Body	Digital Radio Receiver																																								
L	2011	Captiva Sport	Body	HVAC Control Module			V																																					
L	2011	Captiva Sport	Body	Instrument Panel Cluster																																								
L	2011	Captiva Sport	Body	Passenger Presence System																																								
L	2011	Captiva Sport	Body	Radio																																								
L	2011	Captiva Sport	Body	Remote Control Door Lock Receiver																																								
L	2011	Captiva Sport	Body	Rollover Sensor																																								
L	2011	Captiva Sport	Body	Supplemental Inflatable Restraint																																								
L	2011	Captiva Sport	Body	Theft Deterrent Module																																								
L	2011	Equinox	Powertrain	(C) 2.4L LAF Engine Control Module																																								
L	2011	Equinox	Powertrain	(C) 2.4L LAF Transmission Control Module																																								
L	2011	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																								
L	2011	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
L	2011	Equinox	Powertrain	Fuel Pump Control Module																																								
L	2011	Equinox	Powertrain	Rear Differential Clutch Control Module																																								
L	2011	Equinox	Chassis	Electronic Brake Control Module																																								
L	2011	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2011	Equinox	Chassis	Steering Wheel Angle Sensor Module																																								
L	2011	Equinox	Body	Body Control Module																																								
L	2011	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2011	Equinox	Body	Passenger Presence Module																																								
L	2011	Equinox	Body	Instrument Cluster																																								
L	2011	Equinox	Body	Radio																																								
L	2011	Equinox	Body	Multimedia Player Interface Module																																								
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 9																																								
L	2011	Equinox	Body	Telematics Communication Interface Control Module Version 10																																								
L	2011	Equinox	Body	HVAC Control Module Auto Single (C68)																																								
L	2011	Equinox	Body	HVAC Control Module Manual Single (C67)																																								
L	2011	Equinox	Body	Liftgate Control Module																																								
L	2011	Equinox	Body	Parking Assist Control Module																																								
L	2011	Equinox	Body	Frontview Camera Module																																								
L	2011	Equinox	Body	Vehicle Direction Camera Control Module																																								
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
L	2012	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
L	2012	Captiva	Powertrain	2.0L LNP Transmission Control Module																																								
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																								
L	2012	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																								
L	2012	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																								
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																								
L	2012	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																								
L	2012	Captiva	Powertrain	2.4L LE5 Fuel Pump Control Module																																								
L	2012	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																								
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																								
L	2012	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																								
L	2012	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																								
L	2012	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																								
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Automatic Transmission																																								
L	2012	Captiva	Powertrain	3.0L LF1 Engine Control Module Manual Transmission																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2012	Captiva	Powertrain	3.0L LF1 Transmission Control Module																																								
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																								
L	2012	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																								
L	2012	Captiva	Powertrain	(5) 3.0L LFW Fuel Pump Control Module																																								
L	2012	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
L	2012	Captiva	Powertrain	Rear Differential Clutch Control Module																																								
L	2012	Captiva	Chassis	Electronic Brake Control Module																																								
L	2012	Captiva	Chassis	Parking Brake Control Module																																								
L	2012	Captiva	Body	Body Control Module																																								
L	2012	Captiva	Body	Auxiliary Body Control Module																																								
L	2012	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2012	Captiva	Body	Instrument Cluster																																								
L	2012	Captiva	Body	Headlamp Control Module																																								
L	2012	Captiva	Body	HVAC Control Module																																								
L	2012	Captiva	Body	Remote Control Door Lock Receiver																																								
L	2012	Captiva	Body	Parking Assist Control Module																																								
L	2012	Captiva	Body	Theft Deterrent Module																																								
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																								
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Fuel Pump Control Module																																								
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																								
L	2012	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																								
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																								
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Fuel Pump Control Module																																								
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																								
L	2012	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																								
L	2012	Captiva Sport	Chassis	Electronic Brake Control Module																																								
L	2012	Captiva Sport	Chassis	Parking Brake Control Module																																								
L	2012	Captiva Sport	Body	Body Control Module																																								
L	2012	Captiva Sport	Body	Digital Radio Receiver																																								
L	2012	Captiva Sport	Body	HVAC Control Module			V																																					
L	2012	Captiva Sport	Body	Instrument Panel Cluster																																								
L	2012	Captiva Sport	Body	Passenger Presence System																																								
L	2012	Captiva Sport	Body	Radio																																								
L	2012	Captiva Sport	Body	Remote Control Door Lock Receiver																																								
L	2012	Captiva Sport	Body	Rollover Sensor																																								
L	2012	Captiva Sport	Body	Supplemental Inflatable Restraint																																								
L	2012	Captiva Sport	Body	Theft Deterrent Module																																								
L	2012	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																								
L	2012	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
L	2012	Equinox	Powertrain	(5) 3.0L LFW Engine Control Module																																								
L	2012	Equinox	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
L	2012	Equinox	Powertrain	Fuel Pump Control Module																																								
L	2012	Equinox	Powertrain	Rear Differential Clutch Control Module																																								
L	2012	Equinox	Chassis	Electronic Brake Control Module																																								
L	2012	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2012	Equinox	Chassis	Steering Wheel Angle Sensor Module																																								
L	2012	Equinox	Body	Body Control Module																																								
L	2012	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2012	Equinox	Body	Passenger Presence Module																																								
L	2012	Equinox	Body	Instrument Cluster																																								
L	2012	Equinox	Body	Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2012	Equinox	Body	Multimedia Player Interface Module																																								
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 9																																								
L	2012	Equinox	Body	Telematics Communication Interface Control Module Version 10																																								
L	2012	Equinox	Body	HVAC Control Module Auto Single (C68)																																								
L	2012	Equinox	Body	HVAC Control Module Manual Single (C67)																																								
L	2012	Equinox	Body	Liftgate Control Module																																								
L	2012	Equinox	Body	Parking Assist Control Module																																								
L	2012	Equinox	Body	Frontview Camera Module																																								
L	2012	Equinox	Body	Vehicle Direction Camera Control Module																																								
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
L	2013	Captiva	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
L	2013	Captiva	Powertrain	2.0L LNP Transmission Control Module																																								
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																								
L	2013	Captiva	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																								
L	2013	Captiva	Powertrain	2.2L LNQ Transmission Control Module																																								
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																								
L	2013	Captiva	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																								
L	2013	Captiva	Powertrain	2.4L LE5 Transmission Control Module																																								
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																								
L	2013	Captiva	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																								
L	2013	Captiva	Powertrain	2.4L LE9 Fuel Pump Control Module																																								
L	2013	Captiva	Powertrain	2.4L LE9 Transmission Control Module																																								
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																								
L	2013	Captiva	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																								
L	2013	Captiva	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
L	2013	Captiva	Powertrain	Rear Differential Clutch Control Module																																								
L	2013	Captiva	Chassis	Electronic Brake Control Module																																								
L	2013	Captiva	Chassis	Parking Brake Control Module																																								
L	2013	Captiva	Body	Body Control Module HVAC Module Type Auto																																								
L	2013	Captiva	Body	Body Control Module HVAC Module Type Manual																																								
L	2013	Captiva	Body	Auxiliary Body Control Module																																								
L	2013	Captiva	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2013	Captiva	Body	Instrument Cluster																																								
L	2013	Captiva	Body	Headlamp Control Module																																								
L	2013	Captiva	Body	HVAC Control Module																																								
L	2013	Captiva	Body	Remote Control Keyless Type Standard Range (ATG)																																								
L	2013	Captiva	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																								
L	2013	Captiva	Body	Theft Deterrent Module																																								
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Engine Control Module																																								
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Rear Drive System																																								
L	2013	Captiva Sport	Powertrain	(K)2.4L L4 LEA Transmission Control Module																																								
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Engine Control Module																																								
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Rear Drive System																																								
L	2013	Captiva Sport	Powertrain	(5)3.0L V6 LFW Transmission Control Module																																								
L	2013	Captiva Sport	Chassis	Electronic Brake Control Module																																								
L	2013	Captiva Sport	Chassis	Parking Brake Control Module																																								
L	2013	Captiva Sport	Body	Body Control Module																																								
L	2013	Captiva Sport	Body	Digital Radio Receiver																																								
L	2013	Captiva Sport	Body	Heated Seat Module																																								
L	2013	Captiva Sport	Body	HVAC Control Module			V																																					
L	2013	Captiva Sport	Body	Instrument Panel Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2013	Captiva Sport	Body	Park Assist Module																																								
L	2013	Captiva Sport	Body	Passenger Presence System																																								
L	2013	Captiva Sport	Body	Radio																																								
L	2013	Captiva Sport	Body	Remote Control Door Lock Receiver																																								
L	2013	Captiva Sport	Body	Supplemental Inflatable Restraint																																								
L	2013	Captiva Sport	Body	Telematic Veh. Locate and Immo.																																								
L	2013	Captiva Sport	Body	Theft Deterrent Module																																								
L	2013	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																								
L	2013	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
L	2013	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																								
L	2013	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
L	2013	Equinox	Powertrain	Rear Differential Clutch Control Module																																								
L	2013	Equinox	Chassis	Electronic Brake Control Module																																								
L	2013	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2013	Equinox	Chassis	Power Steering Control Module																																								
L	2013	Equinox	Chassis	Steering Wheel Angle Sensor Module																																								
L	2013	Equinox	Body	Body Control Module Mechanical Liftgate																																								
L	2013	Equinox	Body	Body Control Module Power Liftgate (TB5)																																								
L	2013	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2013	Equinox	Body	Passenger Presence Module																																								
L	2013	Equinox	Body	Instrument Cluster																																								
L	2013	Equinox	Body	Radio																																								
L	2013	Equinox	Body	Rear Audio Control Module																																								
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 9																																								
L	2013	Equinox	Body	Telematics Communication Interface Control Module Version 10																																								
L	2013	Equinox	Body	HVAC Control Module Auto Single (C68)																																								
L	2013	Equinox	Body	HVAC Control Module Manual Single (C67)																																								
L	2013	Equinox	Body	Liftgate Control Module																																								
L	2013	Equinox	Body	Front Seat Heating Control Module																																								
L	2013	Equinox	Body	Right Side Object Detection Control Module																																								
L	2013	Equinox	Body	Left Side Object Detection Control Module																																								
L	2013	Equinox	Body	Parking Assist Control Module																																								
L	2013	Equinox	Body	Frontview Camera Module																																								
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																								
L	2014	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																								
L	2014	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
L	2014	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																								
L	2014	Captiva (3GN)	Chassis	Electronic Brake Control Module																																								
L	2014	Captiva (3GN)	Chassis	Parking Brake Control Module																																								
L	2014	Captiva (3GN)	Body	Body Control Module																																								
L	2014	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2014	Captiva (3GN)	Body	Passenger Presence Module																																								
L	2014	Captiva (3GN)	Body	Instrument Cluster																																								
L	2014	Captiva (3GN)	Body	Radio																																								
L	2014	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																								
L	2014	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																								
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 9																																								
L	2014	Captiva (3GN)	Body	Telematics Communication Interface Control Module Version 10																																								
L	2014	Captiva (3GN)	Body	HVAC Control Module																																								
L	2014	Captiva (3GN)	Body	Front Seat Heating Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2014	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																								
L	2014	Captiva (3GN)	Body	Parking Assist Control Module																																								
L	2014	Captiva (3GN)	Body	Theft Deterrent Module																																								
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
L	2014	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
L	2014	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																								
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																								
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																								
L	2014	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																								
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Automatic Transmission																																								
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Engine Control Module Manual Transmission																																								
L	2014	Captiva (Other)	Powertrain	2.4L LE5 Transmission Control Module																																								
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																								
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																								
L	2014	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																								
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																								
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																								
L	2014	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
L	2014	Captiva (Other)	Powertrain	Chassis Control Module																																								
L	2014	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																								
L	2014	Captiva (Other)	Chassis	Electronic Brake Control Module																																								
L	2014	Captiva (Other)	Chassis	Parking Brake Control Module																																								
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																								
L	2014	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																								
L	2014	Captiva (Other)	Body	Auxiliary Body Control Module																																								
L	2014	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2014	Captiva (Other)	Body	Instrument Cluster																																								
L	2014	Captiva (Other)	Body	Headlamp Control Module																																								
L	2014	Captiva (Other)	Body	HVAC Control Module																																								
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																								
L	2014	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																								
L	2014	Captiva (Other)	Body	Theft Deterrent Module																																								
L	2014	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																								
L	2014	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
L	2014	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																								
L	2014	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
L	2014	Equinox	Powertrain	Rear Differential Clutch Control Module																																								
L	2014	Equinox	Chassis	Electronic Brake Control Module																																								
L	2014	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2014	Equinox	Chassis	Power Steering Control Module																																								
L	2014	Equinox	Chassis	Steering Wheel Angle Sensor Module																																								
L	2014	Equinox	Body	Body Control Module Mechanical Liftgate																																								
L	2014	Equinox	Body	Body Control Module Power Liftgate (TB5)																																								
L	2014	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2014	Equinox	Body	Passenger Presence Module																																								
L	2014	Equinox	Body	Instrument Cluster																																								
L	2014	Equinox	Body	Radio																																								
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 9																																								
L	2014	Equinox	Body	Telematics Communication Interface Control Module Version 10																																								
L	2014	Equinox	Body	HVAC Control Module Auto Single (C68)																																								
L	2014	Equinox	Body	HVAC Control Module Manual Single (C67)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2014	Equinox	Body	Liftgate Control Module																																								
L	2014	Equinox	Body	Right Side Object Detection Control Module																																								
L	2014	Equinox	Body	Left Side Object Detection Control Module																																								
L	2014	Equinox	Body	Parking Assist Control Module																																								
L	2014	Equinox	Body	Frontview Camera Module																																								
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																								
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																								
L	2015	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																								
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																								
L	2015	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
L	2015	Captiva (3GN)	Powertrain	Rear Differential Clutch Control Module																																								
L	2015	Captiva (3GN)	Chassis	Electronic Brake Control Module																																								
L	2015	Captiva (3GN)	Chassis	Parking Brake Control Module																																								
L	2015	Captiva (3GN)	Body	Body Control Module																																								
L	2015	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2015	Captiva (3GN)	Body	Passenger Presence Module																																								
L	2015	Captiva (3GN)	Body	Instrument Cluster																																								
L	2015	Captiva (3GN)	Body	Radio																																								
L	2015	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																								
L	2015	Captiva (3GN)	Body	Telematic Vehicle Localization and Immobilzation Control Module																																								
L	2015	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																								
L	2015	Captiva (3GN)	Body	HVAC Control Module																																								
L	2015	Captiva (3GN)	Body	Front Seat Heating Control Module																																								
L	2015	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																								
L	2015	Captiva (3GN)	Body	Parking Assist Control Module																																								
L	2015	Captiva (3GN)	Body	Theft Deterrent Module																																								
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
L	2015	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
L	2015	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																								
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																								
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																								
L	2015	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																								
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																								
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																								
L	2015	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																								
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																								
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																								
L	2015	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
L	2015	Captiva (Other)	Powertrain	Chassis Control Module																																								
L	2015	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																								
L	2015	Captiva (Other)	Chassis	Electronic Brake Control Module																																								
L	2015	Captiva (Other)	Chassis	Parking Brake Control Module																																								
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																								
L	2015	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																								
L	2015	Captiva (Other)	Body	Auxiliary Body Control Module																																								
L	2015	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2015	Captiva (Other)	Body	Instrument Cluster																																								
L	2015	Captiva (Other)	Body	Headlamp Control Module																																								
L	2015	Captiva (Other)	Body	HVAC Control Module																																								
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2015	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																								
L	2015	Captiva (Other)	Body	Theft Deterrent Module																																								
L	2015	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																								
L	2015	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
L	2015	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																								
L	2015	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
L	2015	Equinox	Powertrain	Rear Differential Clutch Control Module																																								
L	2015	Equinox	Chassis	Electronic Brake Control Module																																								
L	2015	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2015	Equinox	Chassis	Power Steering Control Module																																								
L	2015	Equinox	Chassis	Steering Wheel Angle Sensor Module																																								
L	2015	Equinox	Body	Body Control Module Mechanical Liftgate																																								
L	2015	Equinox	Body	Body Control Module Power Liftgate (TB5)																																								
L	2015	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2015	Equinox	Body	Passenger Presence Module																																								
L	2015	Equinox	Body	Instrument Cluster																																								
L	2015	Equinox	Body	Radio																																								
L	2015	Equinox	Body	Telematics Communication Interface Control Module																																								
L	2015	Equinox	Body	HVAC Control Module Auto Single (C68)																																								
L	2015	Equinox	Body	HVAC Control Module Manual Single (C67)																																								
L	2015	Equinox	Body	Liftgate Control Module																																								
L	2015	Equinox	Body	Right Side Object Detection Control Module																																								
L	2015	Equinox	Body	Left Side Object Detection Control Module																																								
L	2015	Equinox	Body	Parking Assist Control Module																																								
L	2015	Equinox	Body	Frontview Camera Module																																								
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Engine Control Module																																								
L	2016	Captiva (3GN)	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Engine Control Module																																								
L	2016	Captiva (3GN)	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
L	2016	Captiva (3GN)	Chassis	Electronic Brake Control Module																																								
L	2016	Captiva (3GN)	Chassis	Parking Brake Control Module																																								
L	2016	Captiva (3GN)	Body	Body Control Module																																								
L	2016	Captiva (3GN)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2016	Captiva (3GN)	Body	Instrument Cluster																																								
L	2016	Captiva (3GN)	Body	Radio																																								
L	2016	Captiva (3GN)	Body	Digital Radio Receiver Control Module																																								
L	2016	Captiva (3GN)	Body	Telematics Communication Interface Control Module																																								
L	2016	Captiva (3GN)	Body	HVAC Control Module																																								
L	2016	Captiva (3GN)	Body	Front Seat Heating Control Module																																								
L	2016	Captiva (3GN)	Body	Remote Control Door Lock Receiver																																								
L	2016	Captiva (3GN)	Body	Parking Assist Control Module																																								
L	2016	Captiva (3GN)	Body	Theft Deterrent Module																																								
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Automatic Transmission																																								
L	2016	Captiva (Other)	Powertrain	2.0L LFS Engine Control Module Manual Transmission																																								
L	2016	Captiva (Other)	Powertrain	2.0L LFS Transmission Control Module																																								
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
L	2016	Captiva (Other)	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
L	2016	Captiva (Other)	Powertrain	2.0L LNP Transmission Control Module																																								
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Automatic Transmission																																								
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Engine Control Module Manual Transmission																																								
L	2016	Captiva (Other)	Powertrain	2.2L LNQ Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Automatic Transmission																																								
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Engine Control Module Manual Transmission																																								
L	2016	Captiva (Other)	Powertrain	2.4L LE9 Transmission Control Module																																								
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Automatic Transmission																																								
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Engine Control Module Manual Transmission																																								
L	2016	Captiva (Other)	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
L	2016	Captiva (Other)	Powertrain	Chassis Control Module																																								
L	2016	Captiva (Other)	Powertrain	Rear Differential Clutch Control Module																																								
L	2016	Captiva (Other)	Chassis	Electronic Brake Control Module																																								
L	2016	Captiva (Other)	Chassis	Parking Brake Control Module																																								
L	2016	Captiva (Other)	Chassis	Power Steering Control Module																																								
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Auto																																								
L	2016	Captiva (Other)	Body	Body Control Module HVAC Module Type Manual																																								
L	2016	Captiva (Other)	Body	Auxiliary Body Control Module																																								
L	2016	Captiva (Other)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2016	Captiva (Other)	Body	Instrument Cluster																																								
L	2016	Captiva (Other)	Body	Headlamp Control Module																																								
L	2016	Captiva (Other)	Body	Radio																																								
L	2016	Captiva (Other)	Body	HVAC Control Module																																								
L	2016	Captiva (Other)	Body	Right Side Object Detection Control Module																																								
L	2016	Captiva (Other)	Body	Left Side Object Detection Control Module																																								
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Standard Range (ATG)																																								
L	2016	Captiva (Other)	Body	Remote Control Keyless Type Extended Range Passive Entry (ATH)																																								
L	2016	Captiva (Other)	Body	Theft Deterrent Module																																								
L	2016	Equinox	Powertrain	(K) 2.4L LEA Engine Control Module																																								
L	2016	Equinox	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
L	2016	Equinox	Powertrain	(3) 3.6L LFX Engine Control Module																																								
L	2016	Equinox	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
L	2016	Equinox	Powertrain	Rear Differential Clutch Control Module																																								
L	2016	Equinox	Chassis	Electronic Brake Control Module																																								
L	2016	Equinox	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2016	Equinox	Chassis	Power Steering Control Module																																								
L	2016	Equinox	Chassis	Steering Wheel Angle Sensor Module																																								
L	2016	Equinox	Body	Body Control Module Mechanical Liftgate																																								
L	2016	Equinox	Body	Body Control Module Power Liftgate (TB5)																																								
L	2016	Equinox	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2016	Equinox	Body	Passenger Presence Module																																								
L	2016	Equinox	Body	Instrument Cluster																																								
L	2016	Equinox	Body	Radio																																								
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 9.7																																								
L	2016	Equinox	Body	Telematics Communication Interface Control Module Version 10																																								
L	2016	Equinox	Body	HVAC Control Module Auto Single (C68)																																								
L	2016	Equinox	Body	HVAC Control Module Manual Single (C67)																																								
L	2016	Equinox	Body	Liftgate Control Module																																								
L	2016	Equinox	Body	Seat Memory Control Module																																								
L	2016	Equinox	Body	Right Side Object Detection Control Module																																								
L	2016	Equinox	Body	Left Side Object Detection Control Module																																								
L	2016	Equinox	Body	Parking Assist Control Module																																								
L	2016	Equinox	Body	Frontview Camera Module																																								
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
M	2004	ALL	Chassis	4WAL 3 Sensor																																								
M	2004	ALL	Body	Body Control Module																																								
M	2004	ALL	Body	Instrument Panel Cluster																																								
M	2004	ALL	Body	Supplemental Inflatable Restraint																																								
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
M	2005	ALL	Chassis	4WAL 3 Sensor																																								
M	2005	ALL	Body	Body Control Module																																								
M	2005	ALL	Body	Instrument Panel Cluster																																								
M	2005	ALL	Body	Supplemental Inflatable Restraint																																								
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																								
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																								
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																								
P	2007	ALL	Body	Supplemental Inflatable Restraint																																								
P	2007	ALL	Body	Theft Deterrent Module																																								
R	2009	ALL	Powertrain	Engine Control Module																																								
R	2009	ALL	Powertrain	Fuel Pump Control Module																																								
R	2009	ALL	Powertrain	Transmission Control Module																																								
R	2009	ALL	Chassis	Electronic Brake Control Module																																								
R	2009	ALL	Body	Body Control Module																																								
R	2009	ALL	Body	Digital Radio Receiver																																								
R	2009	ALL	Body	Driver Door Switch				V																																				
R	2009	ALL	Body	Heated Seat Module																																								
R	2009	ALL	Body	HVAC Control Module Auto																																								
R	2009	ALL	Body	HVAC Control Module Manual																																								
R	2009	ALL	Body	Instrument Panel Cluster																																								
R	2009	ALL	Body	Lift Gate Module																																								
R	2009	ALL	Body	Park Assist Module																																								
R	2009	ALL	Body	Passenger Door Switch				V																																				
R	2009	ALL	Body	Passenger Presence System																																								
R	2009	ALL	Body	Radio																																								
R	2009	ALL	Body	Rear HVAC/RSA																																								
R	2009	ALL	Body	Rollover Sensor																																								
R	2009	ALL	Body	Supplemental Inflatable Restraint																																								
R	2009	ALL	Body	Theft Deterrent Module																																								
R	2010	ALL	Powertrain	Engine Control Module																																								
R	2010	ALL	Powertrain	Fuel Pump Control Module																																								
R	2010	ALL	Powertrain	Transmission Control Module																																								
R	2010	ALL	Chassis	Electronic Brake Control Module																																								
R	2010	ALL	Body	Body Control Module																																								
R	2010	ALL	Body	Digital Radio Receiver																																								
R	2010	ALL	Body	Driver Door Switch				V																																				
R	2010	ALL	Body	Heated Seat Module																																								
R	2010	ALL	Body	HVAC Control Module Auto																																								
R	2010	ALL	Body	HVAC Control Module Manual																																								
R	2010	ALL	Body	Instrument Panel Cluster																																								
R	2010	ALL	Body	Lift Gate Module																																								
R	2010	ALL	Body	Park Assist Module																																								
R	2010	ALL	Body	Passenger Door Switch				V																																				
R	2010	ALL	Body	Passenger Presence System																																								
R	2010	ALL	Body	Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
R	2010	ALL	Body	Rear HVAC/RSA																																								
R	2010	ALL	Body	Supplemental Inflatable Restraint																																								
R	2010	ALL	Body	Theft Deterrent Module																																								
R	2011	ALL	Powertrain	Engine Control Module																																								
R	2011	ALL	Powertrain	Fuel Pump Control Module																																								
R	2011	ALL	Powertrain	Transmission Control Module																																								
R	2011	ALL	Chassis	Electronic Brake Control Module																																								
R	2011	ALL	Body	Body Control Module																																								
R	2011	ALL	Body	Digital Radio Receiver																																								
R	2011	ALL	Body	Driver Door Switch				V																																				
R	2011	ALL	Body	Heated Seat Module																																								
R	2011	ALL	Body	HVAC Control Module Auto																																								
R	2011	ALL	Body	HVAC Control Module Manual																																								
R	2011	ALL	Body	Instrument Panel Cluster																																								
R	2011	ALL	Body	Lift Gate Module																																								
R	2011	ALL	Body	Park Assist Module																																								
R	2011	ALL	Body	Passenger Door Switch				V																																				
R	2011	ALL	Body	Passenger Presence System																																								
R	2011	ALL	Body	Radio																																								
R	2011	ALL	Body	Rear HVAC/RSA																																								
R	2011	ALL	Body	Supplemental Inflatable Restraint																																								
R	2011	ALL	Body	Theft Deterrent Module																																								
R	2012	ALL	Powertrain	Engine Control Module																																								
R	2012	ALL	Powertrain	Fuel Pump Control Module																																								
R	2012	ALL	Powertrain	Transmission Control Module																																								
R	2012	ALL	Chassis	Electronic Brake Control Module																																								
R	2012	ALL	Body	Body Control Module																																								
R	2012	ALL	Body	Digital Radio Receiver																																								
R	2012	ALL	Body	Driver Door Switch				V																																				
R	2012	ALL	Body	Heated Seat Module																																								
R	2012	ALL	Body	HVAC Control Module Auto																																								
R	2012	ALL	Body	HVAC Control Module Manual																																								
R	2012	ALL	Body	Instrument Panel Cluster																																								
R	2012	ALL	Body	Lift Gate Module																																								
R	2012	ALL	Body	Park Assist Module																																								
R	2012	ALL	Body	Passenger Door Switch				V																																				
R	2012	ALL	Body	Passenger Presence System																																								
R	2012	ALL	Body	Radio																																								
R	2012	ALL	Body	Rear HVAC/RSA																																								
R	2012	ALL	Body	Supplemental Inflatable Restraint																																								
R	2012	ALL	Body	Theft Deterrent Module																																								
R	2013	ALL	Powertrain	Engine Control Module																																								
R	2013	ALL	Powertrain	Fuel Pump Control Module																																								
R	2013	ALL	Powertrain	Transmission Control Module																																								
R	2013	ALL	Chassis	Electronic Brake Control Module																																								
R	2013	ALL	Body	Body Control Module																																								
R	2013	ALL	Body	Digital Radio Receiver																																								
R	2013	ALL	Body	Driver Door Switch				V																																				
R	2013	ALL	Body	Heated Seat Module																																								
R	2013	ALL	Body	HVAC Control Module Auto																																								
R	2013	ALL	Body	HVAC Control Module Manual																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
R	2013	ALL	Body	Instrument Panel Cluster																																								
R	2013	ALL	Body	Left Side Object Detection Module																																								
R	2013	ALL	Body	Lift Gate Module																																								
R	2013	ALL	Body	Park Assist Module																																								
R	2013	ALL	Body	Passenger Door Switch				V																																				
R	2013	ALL	Body	Passenger Presence System																																								
R	2013	ALL	Body	Radio																																								
R	2013	ALL	Body	Rear HVAC/RSA																																								
R	2013	ALL	Body	Right Side Object Detection Module																																								
R	2013	ALL	Body	Supplemental Inflatable Restraint																																								
R	2013	ALL	Body	Theft Deterrent Module																																								
R	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																								
R	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
R	2014	Traverse	Powertrain	Chassis Control Module																																								
R	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																								
R	2014	Traverse	Chassis	Electronic Brake Control Module																																								
R	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																								
R	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																								
R	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
R	2014	Traverse	Body	Passenger Presence Module																																								
R	2014	Traverse	Body	Instrument Cluster																																								
R	2014	Traverse	Body	Radio																																								
R	2014	Traverse	Body	Rear Audio Control Module																																								
R	2014	Traverse	Body	Digital Radio Receiver Control Module																																								
R	2014	Traverse	Body	Personal Audio Link Control Module																																								
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																								
R	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																								
R	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																								
R	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																								
R	2014	Traverse	Body	Driver Door Switch Panel Control Module																																								
R	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																								
R	2014	Traverse	Body	Liftgate Control Module																																								
R	2014	Traverse	Body	Seat Memory Control Module																																								
R	2014	Traverse	Body	Front Seat Heating Control Module																																								
R	2014	Traverse	Body	Right Side Object Detection Control Module																																								
R	2014	Traverse	Body	Left Side Object Detection Control Module																																								
R	2014	Traverse	Body	Remote Control Door Lock Receiver																																								
R	2014	Traverse	Body	Parking Assist Control Module																																								
R	2014	Traverse	Body	Frontview Camera Module																																								
R	2014	Traverse	Body	Theft Deterrent Module																																								
R	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																								
R	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
R	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																								
R	2015	Traverse	Chassis	Electronic Brake Control Module																																								
R	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																								
R	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																								
R	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
R	2015	Traverse	Body	Passenger Presence Module																																								
R	2015	Traverse	Body	Instrument Cluster																																								
R	2015	Traverse	Body	Radio																																								
R	2015	Traverse	Body	Digital Radio Receiver Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																								
R	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																								
R	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																								
R	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																								
R	2015	Traverse	Body	Liftgate Control Module																																								
R	2015	Traverse	Body	Seat Memory Control Module																																								
R	2015	Traverse	Body	Front Seat Heating Control Module																																								
R	2015	Traverse	Body	Right Side Object Detection Control Module																																								
R	2015	Traverse	Body	Left Side Object Detection Control Module																																								
R	2015	Traverse	Body	Remote Control Door Lock Receiver																																								
R	2015	Traverse	Body	Parking Assist Control Module																																								
R	2015	Traverse	Body	Frontview Camera Module																																								
R	2015	Traverse	Body	Theft Deterrent Module																																								
R	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																								
R	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
R	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																								
R	2016	Traverse	Chassis	Electronic Brake Control Module																																								
R	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																								
R	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																								
R	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
R	2016	Traverse	Body	Passenger Presence Module																																								
R	2016	Traverse	Body	Instrument Cluster																																								
R	2016	Traverse	Body	Radio																																								
R	2016	Traverse	Body	Rear Audio Control Module																																								
R	2016	Traverse	Body	Digital Radio Receiver Control Module																																								
R	2016	Traverse	Body	Personal Audio Link Control Module																																								
R	2016	Traverse	Body	Telematics Communication Interface Control Module																																								
R	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																								
R	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																								
R	2016	Traverse	Body	Driver Door Switch Panel Control Module																																								
R	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																								
R	2016	Traverse	Body	Liftgate Control Module																																								
R	2016	Traverse	Body	Seat Memory Control Module																																								
R	2016	Traverse	Body	Front Seat Heating Control Module																																								
R	2016	Traverse	Body	Right Side Object Detection Control Module																																								
R	2016	Traverse	Body	Left Side Object Detection Control Module																																								
R	2016	Traverse	Body	Remote Control Door Lock Receiver																																								
R	2016	Traverse	Body	Parking Assist Control Module																																								
R	2016	Traverse	Body	Frontview Camera Module																																								
R	2016	Traverse	Body	Theft Deterrent Module																																								
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
S	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
S	2004	S10	Chassis	4WAL 3 Sensor																																								
S	2004	S10	Chassis	Traction Assist (If Equipped)																																								
S	2004	S10	Body	Body Control Module																																								
S	2004	S10	Body	Instrument Panel Cluster																																								
S	2004	S10	Body	Base Radio																																								
S	2004	S10	Body	Uplevel Radio																																								
S	2004	S10	Body	Supplemental Inflatable Restraint																																								
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																								
S	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																								
S	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																								
S	2004	Colorado	Chassis	ABS Without Traction Control																																								
S	2004	Colorado	Chassis	ABS With Traction Control																																								
S	2004	Colorado	Body	Body Control Module																																								
S	2004	Colorado	Body	Instrument Panel Cluster																																								
S	2004	Colorado	Body	OnStar																																								
S	2004	Colorado	Body	Base Radio																																								
S	2004	Colorado	Body	Uplevel Radio																																								
S	2004	Colorado	Body	Supplemental Inflatable Restraint																																								
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2004	TrailBlazer	Chassis	ABS Without Traction Control																																								
S	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
S	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																								
S	2004	TrailBlazer	Body	Amplifier (Bose)																																								
S	2004	TrailBlazer	Body	Body Control Module																																								
S	2004	TrailBlazer	Body	Driver Door Module																																								
S	2004	TrailBlazer	Body	Driver Seat Module																																								
S	2004	TrailBlazer	Body	Heating and Air Conditioning Auto					V																																			
S	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																								
S	2004	TrailBlazer	Body	Instrument Panel Cluster																																								
S	2004	TrailBlazer	Body	Lift Gate Module																																								
S	2004	TrailBlazer	Body	OnStar																																								
S	2004	TrailBlazer	Body	Passenger Door Module																																								
S	2004	TrailBlazer	Body	Uplevel Radio																																								
S	2004	TrailBlazer	Body	Navigation Radio																																								
S	2004	TrailBlazer	Body	Rear Seat Audio																																								
S	2004	TrailBlazer	Body	Rear Seat Entertainment																																								
S	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																								
S	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																								
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																								
S	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																								
S	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																								
S	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
S	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																								
S	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																								
S	2004	TrailBlazer EXT	Body	Body Control Module																																								
S	2004	TrailBlazer EXT	Body	Driver Door Module																																								
S	2004	TrailBlazer EXT	Body	Driver Seat Module																																								
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto					V																																			
S	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																								
S	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																								
S	2004	TrailBlazer EXT	Body	Lift Gate Module																																								
S	2004	TrailBlazer EXT	Body	OnStar																																								
S	2004	TrailBlazer EXT	Body	Passenger Door Module																																								
S	2004	TrailBlazer EXT	Body	Uplevel Radio																																								
S	2004	TrailBlazer EXT	Body	Navigation Radio																																								
S	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																								
S	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																								
S	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																								
S	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																								
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
S	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
S	2004	Blazer	Chassis	4WAL 3 Sensor																																								
S	2004	Blazer	Chassis	Traction Assist (If Equipped)																																								
S	2004	Blazer	Body	Body Control Module																																								
S	2004	Blazer	Body	Heating and Air Conditioning																																								
S	2004	Blazer	Body	Instrument Panel Cluster																																								
S	2004	Blazer	Body	Memory Seat Module																																								
S	2004	Blazer	Body	Base Radio																																								
S	2004	Blazer	Body	Uplevel Radio																																								
S	2004	Blazer	Body	Supplemental Inflatable Restraint																																								
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																								
S	2004	SSR	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																								
S	2004	SSR	Chassis	4WAL 3 Sensor																																								
S	2004	SSR	Chassis	Traction Assist (If Equipped)																																								
S	2004	SSR	Body	Amplifier (Bose)																																								
S	2004	SSR	Body	Body Control Module																																								
S	2004	SSR	Body	Driver Seat Module																																								
S	2004	SSR	Body	Instrument Panel Cluster																																								
S	2004	SSR	Body	Uplevel Radio																																								
S	2004	SSR	Body	Remote Function Actuation																																								
S	2004	SSR	Body	Roof and Door Module																																								
S	2004	SSR	Body	Supplemental Inflatable Restraint																																								
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																								
S	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																								
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																								
S	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																								
S	2005	Colorado	Chassis	ABS Without Traction Control																																								
S	2005	Colorado	Chassis	ABS With Traction Control																																								
S	2005	Colorado	Body	Body Control Module																																								
S	2005	Colorado	Body	Instrument Panel Cluster																																								
S	2005	Colorado	Body	Base Radio																																								
S	2005	Colorado	Body	Uplevel Radio																																								
S	2005	Colorado	Body	Supplemental Inflatable Restraint																																								
S	2005	Colorado	Body	Vehicle Comm. Interface Module																																								
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2005	TrailBlazer	Chassis	ABS Without Traction Control																																								
S	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
S	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																								
S	2005	TrailBlazer	Body	Body Control Module																																								
S	2005	TrailBlazer	Body	Disc Player and Video Display																																								
S	2005	TrailBlazer	Body	Driver Door Module																																								
S	2005	TrailBlazer	Body	Driver Seat Module																																								
S	2005	TrailBlazer	Body	Heating and Air Conditioning Auto					V																																			
S	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																								
S	2005	TrailBlazer	Body	Instrument Panel Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2005	TrailBlazer	Body	Lift Gate Module																																								
S	2005	TrailBlazer	Body	Passenger Door Module																																								
S	2005	TrailBlazer	Body	Passenger Presence System																																								
S	2005	TrailBlazer	Body	Uplevel Radio																																								
S	2005	TrailBlazer	Body	Navigation Radio																																								
S	2005	TrailBlazer	Body	Rear Seat Audio																																								
S	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																								
S	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																								
S	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																								
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
S	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																								
S	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
S	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																								
S	2005	TrailBlazer EXT	Body	Body Control Module																																								
S	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																								
S	2005	TrailBlazer EXT	Body	Driver Door Module																																								
S	2005	TrailBlazer EXT	Body	Driver Seat Module																																								
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto					V																																			
S	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																								
S	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																								
S	2005	TrailBlazer EXT	Body	Lift Gate Module																																								
S	2005	TrailBlazer EXT	Body	Passenger Door Module																																								
S	2005	TrailBlazer EXT	Body	Passenger Presence System																																								
S	2005	TrailBlazer EXT	Body	Uplevel Radio																																								
S	2005	TrailBlazer EXT	Body	Navigation Radio																																								
S	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																								
S	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																								
S	2005	TrailBlazer EXT	Body	Rear Seat Audio																																								
S	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																								
S	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																								
S	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																								
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
S	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
S	2005	Blazer	Chassis	4WAL 3 Sensor																																								
S	2005	Blazer	Chassis	Traction Assist (If Equipped)																																								
S	2005	Blazer	Body	Body Control Module																																								
S	2005	Blazer	Body	Heating and Air Conditioning																																								
S	2005	Blazer	Body	Instrument Panel Cluster																																								
S	2005	Blazer	Body	Memory Seat Module																																								
S	2005	Blazer	Body	Base Radio																																								
S	2005	Blazer	Body	Uplevel Radio																																								
S	2005	Blazer	Body	Supplemental Inflatable Restraint																																								
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
S	2005	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
S	2005	SSR	Chassis	4WAL 3 Sensor																																								
S	2005	SSR	Chassis	Traction Assist (If Equipped)																																								
S	2005	SSR	Body	Amplifier (Bose)																																								
S	2005	SSR	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2005	SSR	Body	Driver Seat Module																																								
S	2005	SSR	Body	Instrument Panel Cluster																																								
S	2005	SSR	Body	Uplevel Radio																																								
S	2005	SSR	Body	Remote Function Actuation																																								
S	2005	SSR	Body	Roof and Door Module																																								
S	2005	SSR	Body	Supplemental Inflatable Restraint																																								
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																								
S	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																								
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																								
S	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																								
S	2006	Colorado	Chassis	ABS Without Traction Control																																								
S	2006	Colorado	Chassis	ABS With Traction Control																																								
S	2006	Colorado	Body	Body Control Module																																								
S	2006	Colorado	Body	Instrument Panel Cluster																																								
S	2006	Colorado	Body	Passenger Presence System																																								
S	2006	Colorado	Body	Base Radio																																								
S	2006	Colorado	Body	Uplevel Radio																																								
S	2006	Colorado	Body	Supplemental Inflatable Restraint																																								
S	2006	Colorado	Body	Vehicle Comm. Interface Module																																								
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
S	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
S	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
S	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																								
S	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																								
S	2006	TrailBlazer	Body	Body Control Module																																								
S	2006	TrailBlazer	Body	Disc Player and Video Display																																								
S	2006	TrailBlazer	Body	Driver Door Module																																								
S	2006	TrailBlazer	Body	Driver Seat Module																																								
S	2006	TrailBlazer	Body	Heating and Air Conditioning Auto					V																																			
S	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																								
S	2006	TrailBlazer	Body	Instrument Panel Cluster																																								
S	2006	TrailBlazer	Body	Lift Gate Module																																								
S	2006	TrailBlazer	Body	Passenger Door Module																																								
S	2006	TrailBlazer	Body	Passenger Presence System																																								
S	2006	TrailBlazer	Body	Uplevel Radio																																								
S	2006	TrailBlazer	Body	Navigation Radio																																								
S	2006	TrailBlazer	Body	Rear Seat Audio																																								
S	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																								
S	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																								
S	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																								
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
S	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																								
S	2006	TrailBlazer EXT	Body	Body Control Module																																								
S	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																								
S	2006	TrailBlazer EXT	Body	Driver Door Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2006	TrailBlazer EXT	Body	Driver Seat Module																																								
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto					V																																			
S	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																								
S	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																								
S	2006	TrailBlazer EXT	Body	Lift Gate Module																																								
S	2006	TrailBlazer EXT	Body	Passenger Door Module																																								
S	2006	TrailBlazer EXT	Body	Passenger Presence System																																								
S	2006	TrailBlazer EXT	Body	Uplevel Radio																																								
S	2006	TrailBlazer EXT	Body	Navigation Radio																																								
S	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																								
S	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																								
S	2006	TrailBlazer EXT	Body	Rear Seat Audio																																								
S	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																								
S	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																								
S	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																								
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
S	2006	SSR	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
S	2006	SSR	Chassis	4WAL 3 Sensor																																								
S	2006	SSR	Chassis	Traction Assist (If Equipped)																																								
S	2006	SSR	Body	Amplifier (Bose)																																								
S	2006	SSR	Body	Body Control Module																																								
S	2006	SSR	Body	Driver Seat Module																																								
S	2006	SSR	Body	Instrument Panel Cluster																																								
S	2006	SSR	Body	Uplevel Radio																																								
S	2006	SSR	Body	Remote Function Actuation																																								
S	2006	SSR	Body	Roof and Door Module																																								
S	2006	SSR	Body	Supplemental Inflatable Restraint																																								
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
S	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
S	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
S	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																								
S	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																								
S	2007	Colorado	Body	Body Control Module																																								
S	2007	Colorado	Body	Digital Radio Receiver																																								
S	2007	Colorado	Body	Generator Battery Control Module																																								
S	2007	Colorado	Body	Instrument Panel Cluster																																								
S	2007	Colorado	Body	Passenger Presence System																																								
S	2007	Colorado	Body	Base Radio																																								
S	2007	Colorado	Body	Uplevel Radio																																								
S	2007	Colorado	Body	Supplemental Inflatable Restraint																																								
S	2007	Colorado	Body	Vehicle Comm. Interface Module																																								
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																								
S	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																								
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
S	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
S	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
S	2007	Trailblazer	Chassis	Electronic Brake Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2007	Trailblazer	Body	Body Control Module																																								
S	2007	Trailblazer	Body	Digital Radio Receiver																																								
S	2007	Trailblazer	Body	Disc Player and Video Display																																								
S	2007	Trailblazer	Body	Driver Door Module																																								
S	2007	Trailblazer	Body	Driver Seat Module																																								
S	2007	Trailblazer	Body	Generator Battery Control Module																																								
S	2007	Trailblazer	Body	HVAC Control Module Auto					V	V																																		
S	2007	Trailblazer	Body	HVAC Control Module Manual						V																																		
S	2007	Trailblazer	Body	Instrument Panel Cluster																																								
S	2007	Trailblazer	Body	Lift Gate Module							V																																	
S	2007	Trailblazer	Body	Passenger Door Module																																								
S	2007	Trailblazer	Body	Passenger Presence System																																								
S	2007	Trailblazer	Body	Uplevel Radio																																								
S	2007	Trailblazer	Body	Navigation Radio																																								
S	2007	Trailblazer	Body	Rear Seat Audio																																								
S	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																								
S	2007	Trailblazer	Body	Theft Deterrent Module																																								
S	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																								
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
S	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
S	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
S	2008	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																								
S	2008	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																								
S	2008	Colorado	Body	Body Control Module																																								
S	2008	Colorado	Body	Digital Radio Receiver																																								
S	2008	Colorado	Body	Generator Battery Control Module																																								
S	2008	Colorado	Body	Instrument Panel Cluster																																								
S	2008	Colorado	Body	Passenger Presence System																																								
S	2008	Colorado	Body	Base Radio																																								
S	2008	Colorado	Body	Uplevel Radio																																								
S	2008	Colorado	Body	Supplemental Inflatable Restraint																																								
S	2008	Colorado	Body	Theft Deterrent Module																																								
S	2008	Colorado	Body	Vehicle Comm. Interface Module																																								
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
S	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
S	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
S	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																								
S	2008	TrailBlazer	Body	Body Control Module																																								
S	2008	TrailBlazer	Body	Digital Radio Receiver																																								
S	2008	TrailBlazer	Body	Disc Player and Video Display																																								
S	2008	TrailBlazer	Body	Driver Door Module																																								
S	2008	TrailBlazer	Body	Driver Seat Module																																								
S	2008	TrailBlazer	Body	Generator Battery Control Module																																								
S	2008	TrailBlazer	Body	HVAC Control Module Auto					V	V																																		
S	2008	TrailBlazer	Body	HVAC Control Module Manual						V																																		
S	2008	TrailBlazer	Body	Instrument Panel Cluster																																								
S	2008	TrailBlazer	Body	Lift Gate Module							V																																	

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2008	TrailBlazer	Body	Passenger Door Module																																								
S	2008	TrailBlazer	Body	Passenger Presence System																																								
S	2008	TrailBlazer	Body	Uplevel Radio																																								
S	2008	TrailBlazer	Body	Navigation Radio																																								
S	2008	TrailBlazer	Body	Rear Seat Audio																																								
S	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																								
S	2008	TrailBlazer	Body	Theft Deterrent Module																																								
S	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																								
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
S	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
S	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																								
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																								
S	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																								
S	2009	Colorado	Chassis	Electronic Brake Control Module																																								
S	2009	Colorado	Body	Body Control Module																																								
S	2009	Colorado	Body	Digital Radio Receiver																																								
S	2009	Colorado	Body	Generator Battery Control Module																																								
S	2009	Colorado	Body	Instrument Panel Cluster																																								
S	2009	Colorado	Body	Passenger Presence System																																								
S	2009	Colorado	Body	Base Radio																																								
S	2009	Colorado	Body	Uplevel Radio																																								
S	2009	Colorado	Body	Supplemental Inflatable Restraint																																								
S	2009	Colorado	Body	Theft Deterrent Module																																								
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																								
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
S	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																								
S	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																								
S	2009	TrailBlazer	Body	Body Control Module																																								
S	2009	TrailBlazer	Body	Digital Radio Receiver																																								
S	2009	TrailBlazer	Body	Disc Player and Video Display																																								
S	2009	TrailBlazer	Body	Driver Door Module																																								
S	2009	TrailBlazer	Body	Driver Seat Module																																								
S	2009	TrailBlazer	Body	Generator Battery Control Module																																								
S	2009	TrailBlazer	Body	HVAC Control Module Auto					V	V																																		
S	2009	TrailBlazer	Body	HVAC Control Module Manual						V																																		
S	2009	TrailBlazer	Body	Instrument Panel Cluster																																								
S	2009	TrailBlazer	Body	Lift Gate Module							V																																	
S	2009	TrailBlazer	Body	Passenger Door Module																																								
S	2009	TrailBlazer	Body	Passenger Presence System																																								
S	2009	TrailBlazer	Body	Uplevel Radio																																								
S	2009	TrailBlazer	Body	Navigation Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2009	TrailBlazer	Body	Rear Seat Audio																																								
S	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																								
S	2009	TrailBlazer	Body	Theft Deterrent Module																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																								
S	2010	ALL	Chassis	Electronic Brake Control Module																																								
S	2010	ALL	Body	Body Control Module																																								
S	2010	ALL	Body	Digital Radio Receiver																																								
S	2010	ALL	Body	Generator Battery Control Module																																								
S	2010	ALL	Body	Instrument Panel Cluster																																								
S	2010	ALL	Body	Passenger Presence System																																								
S	2010	ALL	Body	Personal Audio Link Module																																								
S	2010	ALL	Body	Base Radio																																								
S	2010	ALL	Body	Uplevel Radio																																								
S	2010	ALL	Body	Supplemental Inflatable Restraint																																								
S	2010	ALL	Body	Theft Deterrent Module																																								
S	2010	ALL	Body	Vehicle Comm. Interface Module								V																																
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
S	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
S	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																								
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																								
S	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																								
S	2011	ALL	Chassis	Electronic Brake Control Module																																								
S	2011	ALL	Body	Body Control Module																																								
S	2011	ALL	Body	Digital Radio Receiver																																								
S	2011	ALL	Body	Generator Battery Control Module																																								
S	2011	ALL	Body	Instrument Panel Cluster																																								
S	2011	ALL	Body	Passenger Presence System																																								
S	2011	ALL	Body	Personal Audio Link Module																																								
S	2011	ALL	Body	Base Radio																																								
S	2011	ALL	Body	Uplevel Radio																																								
S	2011	ALL	Body	Supplemental Inflatable Restraint																																								
S	2011	ALL	Body	Theft Deterrent Module																																								
S	2011	ALL	Body	Vehicle Comm. Interface Module								V																																
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
S	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
S	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																								
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																								
S	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																								
S	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																								
S	2012	Colorado (First Gen)	Body	Body Control Module																																								
S	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																								
S	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																								
S	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																								
S	2012	Colorado (First Gen)	Body	Passenger Presence System																																								
S	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																								
S	2012	Colorado (First Gen)	Body	Base Radio																																								
S	2012	Colorado (First Gen)	Body	Uplevel Radio																																								
S	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																								
S	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																								
S	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module								V																																
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																								
S	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																								
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																								
S	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																								
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																								
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																								
S	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																								
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																								
S	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																								
S	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																								
S	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																								
S	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																								
S	2012	Colorado (Second Gen)	Body	Body Control Module																																								
S	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2012	Colorado (Second Gen)	Body	Instrument Cluster																																								
S	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																								
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																								
S	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																								
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																								
S	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																								
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																								
S	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																								
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																								
S	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																								
S	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																								
S	2012	S10	Powertrain	Transfer Case Control Module																																								
S	2012	S10	Chassis	Electronic Brake Control Module																																								
S	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																								
S	2012	S10	Body	Body Control Module																																								
S	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2012	S10	Body	Instrument Cluster																																								
S	2012	S10	Body	Trailer Interface Control Module																																								
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																								
S	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																								
S	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																								
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																								
S	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																								
S	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																								
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																								
S	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																								
S	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																								
S	2013	Colorado	Powertrain	Transfer Case Control Module																																								
S	2013	Colorado	Chassis	Electronic Brake Control Module																																								
S	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																								
S	2013	Colorado	Body	Body Control Module																																								
S	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2013	Colorado	Body	Instrument Cluster																																								
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																								
S	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																								
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																								
S	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																								
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																								
S	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																								
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																								
S	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																								
S	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																								
S	2013	S10	Powertrain	Transfer Case Control Module																																								
S	2013	S10	Chassis	Electronic Brake Control Module																																								
S	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																								
S	2013	S10	Body	Body Control Module																																								
S	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2013	S10	Body	Instrument Cluster																																								
S	2013	S10	Body	Trailer Interface Control Module																																								
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																								
S	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																								
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																								
S	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																								
S	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																								
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																								
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																								
S	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																								
S	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																								
S	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																								
S	2013	Trailblazer	Powertrain	Transfer Case Control Module																																								
S	2013	Trailblazer	Chassis	Electronic Brake Control Module																																								
S	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																								
S	2013	Trailblazer	Body	Body Control Module																																								
S	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2013	Trailblazer	Body	Instrument Cluster																																								
S	2013	Trailblazer	Body	Trailer Interface Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2013	Trailblazer	Body	Parking Assist Control Module																																								
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																								
S	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																								
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
S	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
S	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
S	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																								
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																								
S	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																								
S	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																								
S	2014	Colorado	Powertrain	Transfer Case Control Module																																								
S	2014	Colorado	Chassis	Electronic Brake Control Module																																								
S	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																								
S	2014	Colorado	Body	Body Control Module																																								
S	2014	Colorado	Body	Body Control Module																																								
S	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2014	Colorado	Body	Instrument Cluster																																								
S	2014	Colorado	Body	Radio																																								
S	2014	Colorado	Body	Telematics Communication Interface Control Module																																								
S	2014	Colorado	Body	Parking Assist Control Module																																								
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																								
S	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																								
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																								
S	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																								
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
S	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
S	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
S	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																								
S	2014	S10	Powertrain	Transfer Case Control Module																																								
S	2014	S10	Chassis	Electronic Brake Control Module																																								
S	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																								
S	2014	S10	Body	Body Control Module																																								
S	2014	S10	Body	Body Control Module																																								
S	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2014	S10	Body	Instrument Cluster																																								
S	2014	S10	Body	Trailer Interface Control Module																																								
S	2014	S10	Body	Radio																																								
S	2014	S10	Body	Parking Assist Control Module																																								
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
S	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
S	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
S	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																								
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																								
S	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																								
S	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																								
S	2014	Trailblazer	Powertrain	Transfer Case Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2014	Trailblazer	Chassis	Electronic Brake Control Module																																								
S	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																								
S	2014	Trailblazer	Body	Body Control Module																																								
S	2014	Trailblazer	Body	Body Control Module																																								
S	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2014	Trailblazer	Body	Instrument Cluster																																								
S	2014	Trailblazer	Body	Trailer Interface Control Module																																								
S	2014	Trailblazer	Body	Parking Assist Control Module																																								
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
S	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
S	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
S	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
S	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
S	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																								
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																								
S	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																								
S	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
S	2015	Colorado	Powertrain	Chassis Control Module																																								
S	2015	Colorado	Powertrain	Transfer Case Control Module																																								
S	2015	Colorado	Chassis	Electronic Brake Control Module																																								
S	2015	Colorado	Chassis	Power Steering Control Module																																								
S	2015	Colorado	Body	Body Control Module																																								
S	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2015	Colorado	Body	Passenger Presence Module																																								
S	2015	Colorado	Body	Radio																																								
S	2015	Colorado	Body	Amplifier																																								
S	2015	Colorado	Body	Human Machine Interface Control Module																																								
S	2015	Colorado	Body	Telematics Communication Interface Control Module																																								
S	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																								
S	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																								
S	2015	Colorado	Body	Frontview Camera Module																																								
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
S	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
S	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
S	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																								
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																								
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																								
S	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
S	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																								
S	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																								
S	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																								
S	2015	Colorado (MMM)	Body	Body Control Module																																								
S	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2015	Colorado (MMM)	Body	Instrument Cluster																																								
S	2015	Colorado (MMM)	Body	Radio																																								
S	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																								
S	2015	Colorado (MMM)	Body	Parking Assist Control Module																																								
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																								
S	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																								
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
S	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
S	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
S	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
S	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
S	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																								
S	2015	S10	Powertrain	Transfer Case Control Module																																								
S	2015	S10	Chassis	Electronic Brake Control Module																																								
S	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																								
S	2015	S10	Body	Body Control Module																																								
S	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2015	S10	Body	Instrument Cluster																																								
S	2015	S10	Body	Trailer Interface Control Module																																								
S	2015	S10	Body	Radio																																								
S	2015	S10	Body	Telematics Communication Interface Control Module																																								
S	2015	S10	Body	Parking Assist Control Module																																								
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
S	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
S	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
S	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																								
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																								
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																								
S	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
S	2015	Trailblazer	Powertrain	Transfer Case Control Module																																								
S	2015	Trailblazer	Chassis	Electronic Brake Control Module																																								
S	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																								
S	2015	Trailblazer	Body	Body Control Module																																								
S	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2015	Trailblazer	Body	Instrument Cluster																																								
S	2015	Trailblazer	Body	Trailer Interface Control Module																																								
S	2015	Trailblazer	Body	Radio																																								
S	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																								
S	2015	Trailblazer	Body	Parking Assist Control Module																																								
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
S	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																								
S	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																								
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																								
S	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																								
S	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																								
S	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																								
S	2016	Colorado (1GC)	Body	Body Control Module																																								
S	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2016	Colorado (1GC)	Body	Passenger Presence Module																																								
S	2016	Colorado (1GC)	Body	Radio Controls																																								
S	2016	Colorado (1GC)	Body	HVAC Controls																																								
S	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																								
S	2016	Colorado (1GC)	Body	Radio																																								
S	2016	Colorado (1GC)	Body	Amplifier																																								
S	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																								
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																								
S	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																								
S	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																								
S	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																								
S	2016	Colorado (1GC)	Body	Frontview Camera Module																																								
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
S	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
S	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																								
S	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																								
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																								
S	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
S	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																								
S	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																								
S	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																								
S	2016	Colorado (MMM)	Body	Body Control Module																																								
S	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2016	Colorado (MMM)	Body	Instrument Cluster																																								
S	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																								
S	2016	Colorado (MMM)	Body	Radio																																								
S	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																								
S	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																								
S	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																								
S	2016	Colorado (MMM)	Body	Parking Assist Control Module																																								
S	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																								
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
S	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
S	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																								
S	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																								
S	2016	S10	Powertrain	Transfer Case Control Module																																								
S	2016	S10	Chassis	Electronic Brake Control Module																																								
S	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																								
S	2016	S10	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2016	S10	Body	Instrument Cluster																																								
S	2016	S10	Body	Trailer Interface Control Module																																								
S	2016	S10	Body	Radio																																								
S	2016	S10	Body	Telematics Communication Interface Control Module																																								
S	2016	S10	Body	HVAC Control Module Auto Single (C68)																																								
S	2016	S10	Body	HVAC Control Module Manual Single (C67)																																								
S	2016	S10	Body	Parking Assist Control Module																																								
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
S	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																								
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																								
S	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																								
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																								
S	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
S	2016	Trailblazer	Powertrain	Transfer Case Control Module																																								
S	2016	Trailblazer	Chassis	Electronic Brake Control Module																																								
S	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																								
S	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																								
S	2016	Trailblazer	Body	Body Control Module																																								
S	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
S	2016	Trailblazer	Body	Instrument Cluster																																								
S	2016	Trailblazer	Body	Trailer Interface Control Module																																								
S	2016	Trailblazer	Body	Radio																																								
S	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																								
S	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																								
S	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																								
S	2016	Trailblazer	Body	Parking Assist Control Module																																								
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
T	2004	S10	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
T	2004	S10	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																								
T	2004	S10	Chassis	4WAL 3 Sensor																																								
T	2004	S10	Chassis	Traction Assist (If Equipped)																																								
T	2004	S10	Body	Body Control Module																																								
T	2004	S10	Body	Instrument Panel Cluster																																								
T	2004	S10	Body	Base Radio																																								
T	2004	S10	Body	Uplevel Radio																																								
T	2004	S10	Body	Supplemental Inflatable Restraint																																								
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																								
T	2004	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																								
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																								
T	2004	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																								
T	2004	Colorado	Chassis	ABS Without Traction Control																																								
T	2004	Colorado	Chassis	ABS With Traction Control																																								
T	2004	Colorado	Body	Body Control Module																																								
T	2004	Colorado	Body	Instrument Panel Cluster																																								
T	2004	Colorado	Body	OnStar																																								
T	2004	Colorado	Body	Base Radio																																								
T	2004	Colorado	Body	Uplevel Radio																																								
T	2004	Colorado	Body	Supplemental Inflatable Restraint																																								
T	2004	Colorado	Body	Instrument Panel Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																								
T	2004	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																								
T	2004	TrailBlazer	Chassis	ABS Without Traction Control																																								
T	2004	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
T	2004	TrailBlazer	Chassis	Traction Assist (If Equipped)																																								
T	2004	TrailBlazer	Body	Amplifier (Bose)																																								
T	2004	TrailBlazer	Body	Body Control Module																																								
T	2004	TrailBlazer	Body	Driver Door Module																																								
T	2004	TrailBlazer	Body	Driver Seat Module																																								
T	2004	TrailBlazer	Body	Heating and Air Conditioning Auto					V																																			
T	2004	TrailBlazer	Body	Heating and Air Conditioning Manual																																								
T	2004	TrailBlazer	Body	Instrument Panel Cluster																																								
T	2004	TrailBlazer	Body	Lift Gate Module																																								
T	2004	TrailBlazer	Body	OnStar																																								
T	2004	TrailBlazer	Body	Passenger Door Module																																								
T	2004	TrailBlazer	Body	Uplevel Radio																																								
T	2004	TrailBlazer	Body	Navigation Radio																																								
T	2004	TrailBlazer	Body	Rear Seat Audio																																								
T	2004	TrailBlazer	Body	Rear Seat Entertainment																																								
T	2004	TrailBlazer	Body	Supplemental Inflatable Restraint																																								
T	2004	TrailBlazer	Body	Vehicle Theft Deterrent																																								
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2004	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																								
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																								
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																								
T	2004	TrailBlazer EXT	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																								
T	2004	TrailBlazer EXT	Chassis	ABS Without Traction Control																																								
T	2004	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
T	2004	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																								
T	2004	TrailBlazer EXT	Body	Amplifier (Bose)																																								
T	2004	TrailBlazer EXT	Body	Body Control Module																																								
T	2004	TrailBlazer EXT	Body	Driver Door Module																																								
T	2004	TrailBlazer EXT	Body	Driver Seat Module																																								
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Auto					V																																			
T	2004	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																								
T	2004	TrailBlazer EXT	Body	Instrument Panel Cluster																																								
T	2004	TrailBlazer EXT	Body	Lift Gate Module																																								
T	2004	TrailBlazer EXT	Body	OnStar																																								
T	2004	TrailBlazer EXT	Body	Passenger Door Module																																								
T	2004	TrailBlazer EXT	Body	Uplevel Radio																																								
T	2004	TrailBlazer EXT	Body	Navigation Radio																																								
T	2004	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																								
T	2004	TrailBlazer EXT	Body	Rear HVAC Manual																																								
T	2004	TrailBlazer EXT	Body	Rear Seat Entertainment																																								
T	2004	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																								
T	2004	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																								
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2004	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																								
T	2004	Blazer	Chassis	4WAL 3 Sensor																																								
T	2004	Blazer	Chassis	Traction Assist (If Equipped)																																								
T	2004	Blazer	Body	Body Control Module																																								
T	2004	Blazer	Body	Heating and Air Conditioning																																								
T	2004	Blazer	Body	Instrument Panel Cluster																																								
T	2004	Blazer	Body	Memory Seat Module																																								
T	2004	Blazer	Body	Base Radio																																								
T	2004	Blazer	Body	Uplevel Radio																																								
T	2004	Blazer	Body	Supplemental Inflatable Restraint																																								
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																								
T	2005	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																								
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																								
T	2005	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																								
T	2005	Colorado	Chassis	ABS Without Traction Control																																								
T	2005	Colorado	Chassis	ABS With Traction Control																																								
T	2005	Colorado	Body	Body Control Module																																								
T	2005	Colorado	Body	Instrument Panel Cluster																																								
T	2005	Colorado	Body	Base Radio																																								
T	2005	Colorado	Body	Uplevel Radio																																								
T	2005	Colorado	Body	Supplemental Inflatable Restraint																																								
T	2005	Colorado	Body	Vehicle Comm. Interface Module																																								
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																								
T	2005	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																								
T	2005	TrailBlazer	Chassis	ABS Without Traction Control																																								
T	2005	TrailBlazer	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
T	2005	TrailBlazer	Chassis	Traction Assist (If Equipped)																																								
T	2005	TrailBlazer	Body	Body Control Module																																								
T	2005	TrailBlazer	Body	Disc Player and Video Display																																								
T	2005	TrailBlazer	Body	Driver Door Module																																								
T	2005	TrailBlazer	Body	Driver Seat Module																																								
T	2005	TrailBlazer	Body	Heating and Air Conditioning Auto					V																																			
T	2005	TrailBlazer	Body	Heating and Air Conditioning Manual																																								
T	2005	TrailBlazer	Body	Instrument Panel Cluster																																								
T	2005	TrailBlazer	Body	Lift Gate Module																																								
T	2005	TrailBlazer	Body	Passenger Door Module																																								
T	2005	TrailBlazer	Body	Passenger Presence System																																								
T	2005	TrailBlazer	Body	Uplevel Radio																																								
T	2005	TrailBlazer	Body	Navigation Radio																																								
T	2005	TrailBlazer	Body	Rear Seat Audio																																								
T	2005	TrailBlazer	Body	Supplemental Inflatable Restraint																																								
T	2005	TrailBlazer	Body	Vehicle Comm. Interface Module																																								
T	2005	TrailBlazer	Body	Vehicle Theft Deterrent																																								
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2005	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																								
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
T	2005	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2005	TrailBlazer EXT	Chassis	ABS Without Traction Control																																								
T	2005	TrailBlazer EXT	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
T	2005	TrailBlazer EXT	Chassis	Traction Assist (If Equipped)																																								
T	2005	TrailBlazer EXT	Body	Body Control Module																																								
T	2005	TrailBlazer EXT	Body	Disc Player and Video Display																																								
T	2005	TrailBlazer EXT	Body	Driver Door Module																																								
T	2005	TrailBlazer EXT	Body	Driver Seat Module																																								
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Auto					V																																			
T	2005	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																								
T	2005	TrailBlazer EXT	Body	Instrument Panel Cluster																																								
T	2005	TrailBlazer EXT	Body	Lift Gate Module																																								
T	2005	TrailBlazer EXT	Body	Passenger Door Module																																								
T	2005	TrailBlazer EXT	Body	Passenger Presence System																																								
T	2005	TrailBlazer EXT	Body	Uplevel Radio																																								
T	2005	TrailBlazer EXT	Body	Navigation Radio																																								
T	2005	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																								
T	2005	TrailBlazer EXT	Body	Rear HVAC Manual																																								
T	2005	TrailBlazer EXT	Body	Rear Seat Audio																																								
T	2005	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																								
T	2005	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																								
T	2005	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																								
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
T	2005	Blazer	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																								
T	2005	Blazer	Chassis	4WAL 3 Sensor																																								
T	2005	Blazer	Chassis	Traction Assist (If Equipped)																																								
T	2005	Blazer	Body	Body Control Module																																								
T	2005	Blazer	Body	Heating and Air Conditioning																																								
T	2005	Blazer	Body	Instrument Panel Cluster																																								
T	2005	Blazer	Body	Memory Seat Module																																								
T	2005	Blazer	Body	Base Radio																																								
T	2005	Blazer	Body	Uplevel Radio																																								
T	2005	Blazer	Body	Supplemental Inflatable Restraint																																								
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																								
T	2006	Colorado	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																								
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Engine Control Module																																								
T	2006	Colorado	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																								
T	2006	Colorado	Chassis	ABS Without Traction Control																																								
T	2006	Colorado	Chassis	ABS With Traction Control																																								
T	2006	Colorado	Body	Body Control Module																																								
T	2006	Colorado	Body	Instrument Panel Cluster																																								
T	2006	Colorado	Body	Passenger Presence System																																								
T	2006	Colorado	Body	Base Radio																																								
T	2006	Colorado	Body	Uplevel Radio																																								
T	2006	Colorado	Body	Supplemental Inflatable Restraint																																								
T	2006	Colorado	Body	Vehicle Comm. Interface Module																																								
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2006	TrailBlazer	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																								
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2006	TrailBlazer	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																								
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
T	2006	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
T	2006	TrailBlazer	Chassis	ABS/TCS/VSES																																								
T	2006	TrailBlazer	Chassis	Tire Pressure Monitor																																								
T	2006	TrailBlazer	Body	Body Control Module																																								
T	2006	TrailBlazer	Body	Disc Player and Video Display																																								
T	2006	TrailBlazer	Body	Driver Door Module																																								
T	2006	TrailBlazer	Body	Driver Seat Module																																								
T	2006	TrailBlazer	Body	Heating and Air Conditioning Auto					V																																			
T	2006	TrailBlazer	Body	Heating and Air Conditioning Manual																																								
T	2006	TrailBlazer	Body	Instrument Panel Cluster																																								
T	2006	TrailBlazer	Body	Lift Gate Module																																								
T	2006	TrailBlazer	Body	Passenger Door Module																																								
T	2006	TrailBlazer	Body	Passenger Presence System																																								
T	2006	TrailBlazer	Body	Uplevel Radio																																								
T	2006	TrailBlazer	Body	Navigation Radio																																								
T	2006	TrailBlazer	Body	Rear Seat Audio																																								
T	2006	TrailBlazer	Body	Supplemental Inflatable Restraint																																								
T	2006	TrailBlazer	Body	Vehicle Theft Deterrent																																								
T	2006	TrailBlazer	Body	Vehicle Comm. Interface Module																																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2006	TrailBlazer EXT	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
T	2006	TrailBlazer EXT	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																								
T	2006	TrailBlazer EXT	Chassis	ABS/TCS/VSES																																								
T	2006	TrailBlazer EXT	Body	Body Control Module																																								
T	2006	TrailBlazer EXT	Body	Disc Player and Video Display																																								
T	2006	TrailBlazer EXT	Body	Driver Door Module																																								
T	2006	TrailBlazer EXT	Body	Driver Seat Module																																								
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Auto					V																																			
T	2006	TrailBlazer EXT	Body	Heating and Air Conditioning Manual																																								
T	2006	TrailBlazer EXT	Body	Instrument Panel Cluster																																								
T	2006	TrailBlazer EXT	Body	Lift Gate Module																																								
T	2006	TrailBlazer EXT	Body	Passenger Door Module																																								
T	2006	TrailBlazer EXT	Body	Passenger Presence System																																								
T	2006	TrailBlazer EXT	Body	Uplevel Radio																																								
T	2006	TrailBlazer EXT	Body	Navigation Radio																																								
T	2006	TrailBlazer EXT	Body	Rear HVAC/RSA Auto																																								
T	2006	TrailBlazer EXT	Body	Rear HVAC Manual																																								
T	2006	TrailBlazer EXT	Body	Rear Seat Audio																																								
T	2006	TrailBlazer EXT	Body	Supplemental Inflatable Restraint																																								
T	2006	TrailBlazer EXT	Body	Vehicle Theft Deterrent																																								
T	2006	TrailBlazer EXT	Body	Vehicle Comm. Interface Module																																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
T	2007	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																								
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2007	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																								
T	2007	Colorado	Chassis	Electronic Brake Control Module Without Traction Control																																								
T	2007	Colorado	Chassis	Electronic Brake Control Module With Traction Control																																								
T	2007	Colorado	Body	Body Control Module																																								
T	2007	Colorado	Body	Digital Radio Receiver																																								
T	2007	Colorado	Body	Generator Battery Control Module																																								
T	2007	Colorado	Body	Instrument Panel Cluster																																								
T	2007	Colorado	Body	Passenger Presence System																																								
T	2007	Colorado	Body	Base Radio																																								
T	2007	Colorado	Body	Uplevel Radio																																								
T	2007	Colorado	Body	Supplemental Inflatable Restraint																																								
T	2007	Colorado	Body	Vehicle Comm. Interface Module																																								
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																								
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																								
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																								
T	2007	Trailblazer	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																								
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
T	2007	Trailblazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																								
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
T	2007	Trailblazer	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																								
T	2007	Trailblazer	Chassis	Electronic Brake Control Module																																								
T	2007	Trailblazer	Body	Body Control Module																																								
T	2007	Trailblazer	Body	Digital Radio Receiver																																								
T	2007	Trailblazer	Body	Disc Player and Video Display																																								
T	2007	Trailblazer	Body	Driver Door Module																																								
T	2007	Trailblazer	Body	Driver Seat Module																																								
T	2007	Trailblazer	Body	Generator Battery Control Module																																								
T	2007	Trailblazer	Body	HVAC Control Module Auto					V	V																																		
T	2007	Trailblazer	Body	HVAC Control Module Manual						V																																		
T	2007	Trailblazer	Body	Instrument Panel Cluster																																								
T	2007	Trailblazer	Body	Lift Gate Module							V																																	
T	2007	Trailblazer	Body	Passenger Door Module																																								
T	2007	Trailblazer	Body	Passenger Presence System																																								
T	2007	Trailblazer	Body	Uplevel Radio																																								
T	2007	Trailblazer	Body	Navigation Radio																																								
T	2007	Trailblazer	Body	Rear Seat Audio																																								
T	2007	Trailblazer	Body	Supplemental Inflatable Restraint																																								
T	2007	Trailblazer	Body	Theft Deterrent Module																																								
T	2007	Trailblazer	Body	Vehicle Comm. Interface Module																																								
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
T	2008	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																								
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
T	2008	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																								
T	2008	Colorado	Chassis	Electronic Brake Control Module																																								
T	2008	Colorado	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2008	Colorado	Body	Digital Radio Receiver																																								
T	2008	Colorado	Body	Generator Battery Control Module																																								
T	2008	Colorado	Body	Instrument Panel Cluster																																								
T	2008	Colorado	Body	Passenger Presence System																																								
T	2008	Colorado	Body	Base Radio																																								
T	2008	Colorado	Body	Uplevel Radio																																								
T	2008	Colorado	Body	Supplemental Inflatable Restraint																																								
T	2008	Colorado	Body	Theft Deterrent Module																																								
T	2008	Colorado	Body	Vehicle Comm. Interface Module																																								
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2008	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																								
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
T	2008	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																								
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
T	2008	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
T	2008	TrailBlazer	Chassis	Electronic Brake Control Module																																								
T	2008	TrailBlazer	Body	Body Control Module																																								
T	2008	TrailBlazer	Body	Digital Radio Receiver																																								
T	2008	TrailBlazer	Body	Disc Player and Video Display																																								
T	2008	TrailBlazer	Body	Driver Door Module																																								
T	2008	TrailBlazer	Body	Driver Seat Module																																								
T	2008	TrailBlazer	Body	Generator Battery Control Module																																								
T	2008	TrailBlazer	Body	HVAC Control Module Auto					V	V																																		
T	2008	TrailBlazer	Body	HVAC Control Module Manual						V																																		
T	2008	TrailBlazer	Body	Instrument Panel Cluster																																								
T	2008	TrailBlazer	Body	Lift Gate Module							V																																	
T	2008	TrailBlazer	Body	Passenger Door Module																																								
T	2008	TrailBlazer	Body	Passenger Presence System																																								
T	2008	TrailBlazer	Body	Uplevel Radio																																								
T	2008	TrailBlazer	Body	Navigation Radio																																								
T	2008	TrailBlazer	Body	Rear Seat Audio																																								
T	2008	TrailBlazer	Body	Supplemental Inflatable Restraint																																								
T	2008	TrailBlazer	Body	Theft Deterrent Module																																								
T	2008	TrailBlazer	Body	Vehicle Comm. Interface Module																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
T	2009	Colorado	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
T	2009	Colorado	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																								
T	2009	Colorado	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																								
T	2009	Colorado	Chassis	Electronic Brake Control Module																																								
T	2009	Colorado	Body	Body Control Module																																								
T	2009	Colorado	Body	Digital Radio Receiver																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2009	Colorado	Body	Generator Battery Control Module																																								
T	2009	Colorado	Body	Instrument Panel Cluster																																								
T	2009	Colorado	Body	Passenger Presence System																																								
T	2009	Colorado	Body	Base Radio																																								
T	2009	Colorado	Body	Uplevel Radio																																								
T	2009	Colorado	Body	Supplemental Inflatable Restraint																																								
T	2009	Colorado	Body	Theft Deterrent Module																																								
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2009	TrailBlazer	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																								
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
T	2009	TrailBlazer	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																								
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
T	2009	TrailBlazer	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
T	2009	TrailBlazer	Chassis	Electronic Brake Control Module																																								
T	2009	TrailBlazer	Body	Body Control Module																																								
T	2009	TrailBlazer	Body	Digital Radio Receiver																																								
T	2009	TrailBlazer	Body	Disc Player and Video Display																																								
T	2009	TrailBlazer	Body	Driver Door Module																																								
T	2009	TrailBlazer	Body	Driver Seat Module																																								
T	2009	TrailBlazer	Body	Generator Battery Control Module																																								
T	2009	TrailBlazer	Body	HVAC Control Module Auto					V	V																																		
T	2009	TrailBlazer	Body	HVAC Control Module Manual						V																																		
T	2009	TrailBlazer	Body	Instrument Panel Cluster																																								
T	2009	TrailBlazer	Body	Lift Gate Module							V																																	
T	2009	TrailBlazer	Body	Passenger Door Module																																								
T	2009	TrailBlazer	Body	Passenger Presence System																																								
T	2009	TrailBlazer	Body	Uplevel Radio																																								
T	2009	TrailBlazer	Body	Navigation Radio																																								
T	2009	TrailBlazer	Body	Rear Seat Audio																																								
T	2009	TrailBlazer	Body	Supplemental Inflatable Restraint																																								
T	2009	TrailBlazer	Body	Theft Deterrent Module																																								
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																								
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																								
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																								
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																								
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																								
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																								
T	2010	ALL	Chassis	Electronic Brake Control Module																																								
T	2010	ALL	Body	Body Control Module																																								
T	2010	ALL	Body	Digital Radio Receiver																																								
T	2010	ALL	Body	Generator Battery Control Module																																								
T	2010	ALL	Body	Instrument Panel Cluster																																								
T	2010	ALL	Body	Passenger Presence System																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2010	ALL	Body	Personal Audio Link Module																																								
T	2010	ALL	Body	Base Radio																																								
T	2010	ALL	Body	Uplevel Radio																																								
T	2010	ALL	Body	Supplemental Inflatable Restraint																																								
T	2010	ALL	Body	Theft Deterrent Module																																								
T	2010	ALL	Body	Vehicle Comm. Interface Module								V																																
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
T	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
T	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																								
T	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																								
T	2011	ALL	Chassis	Electronic Brake Control Module																																								
T	2011	ALL	Body	Body Control Module																																								
T	2011	ALL	Body	Digital Radio Receiver																																								
T	2011	ALL	Body	Generator Battery Control Module																																								
T	2011	ALL	Body	Instrument Panel Cluster																																								
T	2011	ALL	Body	Passenger Presence System																																								
T	2011	ALL	Body	Personal Audio Link Module																																								
T	2011	ALL	Body	Base Radio																																								
T	2011	ALL	Body	Uplevel Radio																																								
T	2011	ALL	Body	Supplemental Inflatable Restraint																																								
T	2011	ALL	Body	Theft Deterrent Module																																								
T	2011	ALL	Body	Vehicle Comm. Interface Module								V																																
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
T	2012	Colorado (First Gen)	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
T	2012	Colorado (First Gen)	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																								
T	2012	Colorado (First Gen)	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																								
T	2012	Colorado (First Gen)	Chassis	Electronic Brake Control Module																																								
T	2012	Colorado (First Gen)	Body	Body Control Module																																								
T	2012	Colorado (First Gen)	Body	Digital Radio Receiver																																								
T	2012	Colorado (First Gen)	Body	Generator Battery Control Module																																								
T	2012	Colorado (First Gen)	Body	Instrument Panel Cluster																																								
T	2012	Colorado (First Gen)	Body	Passenger Presence System																																								
T	2012	Colorado (First Gen)	Body	Personal Audio Link Module																																								
T	2012	Colorado (First Gen)	Body	Base Radio																																								
T	2012	Colorado (First Gen)	Body	Uplevel Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2012	Colorado (First Gen)	Body	Supplemental Inflatable Restraint																																								
T	2012	Colorado (First Gen)	Body	Theft Deterrent Module																																								
T	2012	Colorado (First Gen)	Body	Vehicle Comm. Interface Module								V																																
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																								
T	2012	Colorado (Second Gen)	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																								
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																								
T	2012	Colorado (Second Gen)	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																								
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																								
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																								
T	2012	Colorado (Second Gen)	Powertrain	2.8L LWH Transmission Control Module																																								
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Engine Control Module																																								
T	2012	Colorado (Second Gen)	Powertrain	3.6L LY7 Transmission Control Module																																								
T	2012	Colorado (Second Gen)	Powertrain	Transfer Case Control Module																																								
T	2012	Colorado (Second Gen)	Chassis	Electronic Brake Control Module																																								
T	2012	Colorado (Second Gen)	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2012	Colorado (Second Gen)	Chassis	Steering Wheel Angle Sensor Module																																								
T	2012	Colorado (Second Gen)	Body	Body Control Module																																								
T	2012	Colorado (Second Gen)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2012	Colorado (Second Gen)	Body	Instrument Cluster																																								
T	2012	Colorado (Second Gen)	Body	Trailer Interface Control Module																																								
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																								
T	2012	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																								
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																								
T	2012	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																								
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																								
T	2012	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																								
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																								
T	2012	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																								
T	2012	S10	Powertrain	2.8L LWH Transmission Control Module																																								
T	2012	S10	Powertrain	Transfer Case Control Module																																								
T	2012	S10	Chassis	Electronic Brake Control Module																																								
T	2012	S10	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2012	S10	Chassis	Steering Wheel Angle Sensor Module																																								
T	2012	S10	Body	Body Control Module																																								
T	2012	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2012	S10	Body	Instrument Cluster																																								
T	2012	S10	Body	Trailer Interface Control Module																																								
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																								
T	2013	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																								
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																								
T	2013	Colorado	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																								
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																								
T	2013	Colorado	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																								
T	2013	Colorado	Powertrain	2.8L LWH Transmission Control Module																																								
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																								
T	2013	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																								
T	2013	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																								
T	2013	Colorado	Powertrain	Transfer Case Control Module																																								
T	2013	Colorado	Chassis	Electronic Brake Control Module																																								
T	2013	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2013	Colorado	Chassis	Steering Wheel Angle Sensor Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2013	Colorado	Body	Body Control Module																																								
T	2013	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2013	Colorado	Body	Instrument Cluster																																								
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																								
T	2013	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																								
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																								
T	2013	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																								
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																								
T	2013	S10	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																								
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																								
T	2013	S10	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																								
T	2013	S10	Powertrain	2.8L LWH Transmission Control Module																																								
T	2013	S10	Powertrain	Transfer Case Control Module																																								
T	2013	S10	Chassis	Electronic Brake Control Module																																								
T	2013	S10	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2013	S10	Chassis	Steering Wheel Angle Sensor Module																																								
T	2013	S10	Body	Body Control Module																																								
T	2013	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2013	S10	Body	Instrument Cluster																																								
T	2013	S10	Body	Trailer Interface Control Module																																								
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Automatic Transmission																																								
T	2013	Trailblazer	Powertrain	2.5L LVN Engine Control Module Manual Transmission																																								
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Automatic Transmission																																								
T	2013	Trailblazer	Powertrain	2.8L LWH Engine Control Module Manual Transmission																																								
T	2013	Trailblazer	Powertrain	2.8L LWH Transmission Control Module																																								
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																								
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																								
T	2013	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																								
T	2013	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																								
T	2013	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																								
T	2013	Trailblazer	Powertrain	Transfer Case Control Module																																								
T	2013	Trailblazer	Chassis	Electronic Brake Control Module																																								
T	2013	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2013	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																								
T	2013	Trailblazer	Body	Body Control Module																																								
T	2013	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2013	Trailblazer	Body	Instrument Cluster																																								
T	2013	Trailblazer	Body	Trailer Interface Control Module																																								
T	2013	Trailblazer	Body	Parking Assist Control Module																																								
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																								
T	2014	Colorado	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																								
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
T	2014	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
T	2014	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
T	2014	Colorado	Powertrain	2.8L LWN Transmission Control Module																																								
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																								
T	2014	Colorado	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																								
T	2014	Colorado	Powertrain	3.6L LY7 Transmission Control Module																																								
T	2014	Colorado	Powertrain	Transfer Case Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2014	Colorado	Chassis	Electronic Brake Control Module																																								
T	2014	Colorado	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2014	Colorado	Chassis	Steering Wheel Angle Sensor Module																																								
T	2014	Colorado	Body	Body Control Module																																								
T	2014	Colorado	Body	Body Control Module																																								
T	2014	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2014	Colorado	Body	Instrument Cluster																																								
T	2014	Colorado	Body	Radio																																								
T	2014	Colorado	Body	Telematics Communication Interface Control Module																																								
T	2014	Colorado	Body	Parking Assist Control Module																																								
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Automatic Transmission																																								
T	2014	S10	Powertrain	2.4L LE6 Engine Control Module Manual Transmission																																								
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																								
T	2014	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																								
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
T	2014	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
T	2014	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
T	2014	S10	Powertrain	2.8L LWN Transmission Control Module																																								
T	2014	S10	Powertrain	Transfer Case Control Module																																								
T	2014	S10	Chassis	Electronic Brake Control Module																																								
T	2014	S10	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2014	S10	Chassis	Steering Wheel Angle Sensor Module																																								
T	2014	S10	Body	Body Control Module																																								
T	2014	S10	Body	Body Control Module																																								
T	2014	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2014	S10	Body	Instrument Cluster																																								
T	2014	S10	Body	Trailer Interface Control Module																																								
T	2014	S10	Body	Radio																																								
T	2014	S10	Body	Parking Assist Control Module																																								
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
T	2014	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
T	2014	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
T	2014	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																								
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Automatic Transmission																																								
T	2014	Trailblazer	Powertrain	3.6L LY7 Engine Control Module Manual Transmission																																								
T	2014	Trailblazer	Powertrain	3.6L LY7 Transmission Control Module																																								
T	2014	Trailblazer	Powertrain	Transfer Case Control Module																																								
T	2014	Trailblazer	Chassis	Electronic Brake Control Module																																								
T	2014	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2014	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																								
T	2014	Trailblazer	Body	Body Control Module																																								
T	2014	Trailblazer	Body	Body Control Module																																								
T	2014	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2014	Trailblazer	Body	Instrument Cluster																																								
T	2014	Trailblazer	Body	Trailer Interface Control Module																																								
T	2014	Trailblazer	Body	Parking Assist Control Module																																								
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
T	2015	Colorado	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
T	2015	Colorado	Powertrain	(A) 2.5L LCV Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
T	2015	Colorado	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
T	2015	Colorado	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
T	2015	Colorado	Powertrain	2.8L LWN Transmission Control Module																																								
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																								
T	2015	Colorado	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																								
T	2015	Colorado	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
T	2015	Colorado	Powertrain	Chassis Control Module																																								
T	2015	Colorado	Powertrain	Transfer Case Control Module																																								
T	2015	Colorado	Chassis	Electronic Brake Control Module																																								
T	2015	Colorado	Chassis	Power Steering Control Module																																								
T	2015	Colorado	Body	Body Control Module																																								
T	2015	Colorado	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2015	Colorado	Body	Passenger Presence Module																																								
T	2015	Colorado	Body	Radio																																								
T	2015	Colorado	Body	Amplifier																																								
T	2015	Colorado	Body	Human Machine Interface Control Module																																								
T	2015	Colorado	Body	Telematics Communication Interface Control Module																																								
T	2015	Colorado	Body	HVAC Control Module Auto Single (C68)																																								
T	2015	Colorado	Body	HVAC Control Module Manual Single (C67)																																								
T	2015	Colorado	Body	Frontview Camera Module																																								
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
T	2015	Colorado (MMM)	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
T	2015	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
T	2015	Colorado (MMM)	Powertrain	2.8L LWN Transmission Control Module																																								
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																								
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																								
T	2015	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
T	2015	Colorado (MMM)	Powertrain	Transfer Case Control Module																																								
T	2015	Colorado (MMM)	Chassis	Electronic Brake Control Module																																								
T	2015	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2015	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																								
T	2015	Colorado (MMM)	Body	Body Control Module																																								
T	2015	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2015	Colorado (MMM)	Body	Instrument Cluster																																								
T	2015	Colorado (MMM)	Body	Radio																																								
T	2015	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																								
T	2015	Colorado (MMM)	Body	Parking Assist Control Module																																								
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Automatic Transmission																																								
T	2015	S10	Powertrain	2.4L LP8 Engine Control Module Manual Transmission																																								
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
T	2015	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
T	2015	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
T	2015	S10	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2015	S10	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
T	2015	S10	Powertrain	2.8L LWN Transmission Control Module																																								
T	2015	S10	Powertrain	Transfer Case Control Module																																								
T	2015	S10	Chassis	Electronic Brake Control Module																																								
T	2015	S10	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2015	S10	Chassis	Steering Wheel Angle Sensor Module																																								
T	2015	S10	Body	Body Control Module																																								
T	2015	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2015	S10	Body	Instrument Cluster																																								
T	2015	S10	Body	Trailer Interface Control Module																																								
T	2015	S10	Body	Radio																																								
T	2015	S10	Body	Telematics Communication Interface Control Module																																								
T	2015	S10	Body	Parking Assist Control Module																																								
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
T	2015	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Automatic Transmission																																								
T	2015	Trailblazer	Powertrain	2.8L LWN Engine Control Module Manual Transmission																																								
T	2015	Trailblazer	Powertrain	2.8L LWN Transmission Control Module																																								
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																								
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																								
T	2015	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
T	2015	Trailblazer	Powertrain	Transfer Case Control Module																																								
T	2015	Trailblazer	Chassis	Electronic Brake Control Module																																								
T	2015	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2015	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																								
T	2015	Trailblazer	Body	Body Control Module																																								
T	2015	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2015	Trailblazer	Body	Instrument Cluster																																								
T	2015	Trailblazer	Body	Trailer Interface Control Module																																								
T	2015	Trailblazer	Body	Radio																																								
T	2015	Trailblazer	Body	Telematics Communication Interface Control Module																																								
T	2015	Trailblazer	Body	Parking Assist Control Module																																								
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
T	2016	Colorado (1GC)	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Engine Control Module																																								
T	2016	Colorado (1GC)	Powertrain	(1) 2.8L LWN Transmission Control Module																																								
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Engine Control Module																																								
T	2016	Colorado (1GC)	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
T	2016	Colorado (1GC)	Powertrain	Transfer Case Control Module																																								
T	2016	Colorado (1GC)	Chassis	Electronic Brake Control Module																																								
T	2016	Colorado (1GC)	Chassis	Power Steering Control Module																																								
T	2016	Colorado (1GC)	Body	Body Control Module																																								
T	2016	Colorado (1GC)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2016	Colorado (1GC)	Body	Passenger Presence Module																																								
T	2016	Colorado (1GC)	Body	Radio Controls																																								
T	2016	Colorado (1GC)	Body	HVAC Controls																																								
T	2016	Colorado (1GC)	Body	Trailer Interface Control Module																																								
T	2016	Colorado (1GC)	Body	Radio																																								
T	2016	Colorado (1GC)	Body	Amplifier																																								
T	2016	Colorado (1GC)	Body	Human Machine Interface Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 9.7																																								
T	2016	Colorado (1GC)	Body	Telematics Communication Interface Control Module Version 10																																								
T	2016	Colorado (1GC)	Body	HVAC Control Module Auto Single (C68)																																								
T	2016	Colorado (1GC)	Body	HVAC Control Module Manual Single (C67)																																								
T	2016	Colorado (1GC)	Body	Frontview Camera Module																																								
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
T	2016	Colorado (MMM)	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
T	2016	Colorado (MMM)	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																								
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																								
T	2016	Colorado (MMM)	Powertrain	(1) 2.8L LWN Transmission Control Module																																								
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Engine Control Module																																								
T	2016	Colorado (MMM)	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
T	2016	Colorado (MMM)	Powertrain	Transfer Case Control Module																																								
T	2016	Colorado (MMM)	Chassis	Electronic Brake Control Module																																								
T	2016	Colorado (MMM)	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2016	Colorado (MMM)	Chassis	Steering Wheel Angle Sensor Module																																								
T	2016	Colorado (MMM)	Body	Body Control Module																																								
T	2016	Colorado (MMM)	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2016	Colorado (MMM)	Body	Instrument Cluster																																								
T	2016	Colorado (MMM)	Body	Trailer Interface Control Module																																								
T	2016	Colorado (MMM)	Body	Radio																																								
T	2016	Colorado (MMM)	Body	Telematics Communication Interface Control Module																																								
T	2016	Colorado (MMM)	Body	HVAC Control Module Auto Single (C68)																																								
T	2016	Colorado (MMM)	Body	HVAC Control Module Manual Single (C67)																																								
T	2016	Colorado (MMM)	Body	Parking Assist Control Module																																								
T	2016	S10	Powertrain	2.4L LP8 Engine Control Module																																								
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
T	2016	S10	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
T	2016	S10	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																								
T	2016	S10	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																								
T	2016	S10	Powertrain	(1) 2.8L LWN Transmission Control Module																																								
T	2016	S10	Powertrain	Transfer Case Control Module																																								
T	2016	S10	Chassis	Electronic Brake Control Module																																								
T	2016	S10	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2016	S10	Chassis	Steering Wheel Angle Sensor Module																																								
T	2016	S10	Body	Body Control Module																																								
T	2016	S10	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2016	S10	Body	Instrument Cluster																																								
T	2016	S10	Body	Trailer Interface Control Module																																								
T	2016	S10	Body	Radio																																								
T	2016	S10	Body	Telematics Communication Interface Control Module																																								
T	2016	S10	Body	HVAC Control Module Auto Single (C68)																																								
T	2016	S10	Body	HVAC Control Module Manual Single (C67)																																								
T	2016	S10	Body	Parking Assist Control Module																																								
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Automatic Transmission																																								
T	2016	Trailblazer	Powertrain	2.5L LKH Engine Control Module Manual Transmission																																								
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Automatic Transmission																																								
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Engine Control Module Manual Transmission																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2016	Trailblazer	Powertrain	(1) 2.8L LWN Transmission Control Module																																								
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Engine Control Module																																								
T	2016	Trailblazer	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
T	2016	Trailblazer	Powertrain	Transfer Case Control Module																																								
T	2016	Trailblazer	Chassis	Electronic Brake Control Module																																								
T	2016	Trailblazer	Chassis	Multi-Axis Acceleration Sensor Module																																								
T	2016	Trailblazer	Chassis	Steering Wheel Angle Sensor Module																																								
T	2016	Trailblazer	Body	Body Control Module																																								
T	2016	Trailblazer	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
T	2016	Trailblazer	Body	Instrument Cluster																																								
T	2016	Trailblazer	Body	Trailer Interface Control Module																																								
T	2016	Trailblazer	Body	Radio																																								
T	2016	Trailblazer	Body	Telematics Communication Interface Control Module																																								
T	2016	Trailblazer	Body	HVAC Control Module Auto Single (C68)																																								
T	2016	Trailblazer	Body	HVAC Control Module Manual Single (C67)																																								
T	2016	Trailblazer	Body	Parking Assist Control Module																																								
V	2009	ALL	Powertrain	Engine Control Module																																								
V	2009	ALL	Powertrain	Fuel Pump Control Module																																								
V	2009	ALL	Powertrain	Rear Drive System																																								
V	2009	ALL	Powertrain	Transmission Control Module																																								
V	2009	ALL	Chassis	Electronic Brake Control Module																																								
V	2009	ALL	Body	Body Control Module																																								
V	2009	ALL	Body	Digital Radio Receiver																																								
V	2009	ALL	Body	Driver Door Switch				V																																				
V	2009	ALL	Body	Heated Seat Module																																								
V	2009	ALL	Body	HVAC Control Module Auto																																								
V	2009	ALL	Body	HVAC Control Module Manual																																								
V	2009	ALL	Body	Instrument Panel Cluster																																								
V	2009	ALL	Body	Lift Gate Module																																								
V	2009	ALL	Body	Park Assist Module																																								
V	2009	ALL	Body	Passenger Door Switch				V																																				
V	2009	ALL	Body	Passenger Presence System																																								
V	2009	ALL	Body	Radio																																								
V	2009	ALL	Body	Rear HVAC/RSA																																								
V	2009	ALL	Body	Rollover Sensor																																								
V	2009	ALL	Body	Supplemental Inflatable Restraint																																								
V	2009	ALL	Body	Theft Deterrent Module																																								
V	2010	ALL	Powertrain	Engine Control Module																																								
V	2010	ALL	Powertrain	Fuel Pump Control Module																																								
V	2010	ALL	Powertrain	Rear Drive System																																								
V	2010	ALL	Powertrain	Transmission Control Module																																								
V	2010	ALL	Chassis	Electronic Brake Control Module																																								
V	2010	ALL	Body	Body Control Module																																								
V	2010	ALL	Body	Digital Radio Receiver																																								
V	2010	ALL	Body	Driver Door Switch				V																																				
V	2010	ALL	Body	Heated Seat Module																																								
V	2010	ALL	Body	HVAC Control Module Auto																																								
V	2010	ALL	Body	HVAC Control Module Manual																																								
V	2010	ALL	Body	Instrument Panel Cluster																																								
V	2010	ALL	Body	Lift Gate Module																																								
V	2010	ALL	Body	Park Assist Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
V	2010	ALL	Body	Passenger Door Switch				V																																				
V	2010	ALL	Body	Passenger Presence System																																								
V	2010	ALL	Body	Radio																																								
V	2010	ALL	Body	Rear HVAC/RSA																																								
V	2010	ALL	Body	Supplemental Inflatable Restraint																																								
V	2010	ALL	Body	Theft Deterrent Module																																								
V	2011	ALL	Powertrain	Engine Control Module																																								
V	2011	ALL	Powertrain	Fuel Pump Control Module																																								
V	2011	ALL	Powertrain	Rear Drive System																																								
V	2011	ALL	Powertrain	Transmission Control Module																																								
V	2011	ALL	Chassis	Electronic Brake Control Module																																								
V	2011	ALL	Body	Body Control Module																																								
V	2011	ALL	Body	Digital Radio Receiver																																								
V	2011	ALL	Body	Driver Door Switch				V																																				
V	2011	ALL	Body	Heated Seat Module																																								
V	2011	ALL	Body	HVAC Control Module Auto																																								
V	2011	ALL	Body	HVAC Control Module Manual																																								
V	2011	ALL	Body	Instrument Panel Cluster																																								
V	2011	ALL	Body	Lift Gate Module																																								
V	2011	ALL	Body	Park Assist Module																																								
V	2011	ALL	Body	Passenger Door Switch				V																																				
V	2011	ALL	Body	Passenger Presence System																																								
V	2011	ALL	Body	Radio																																								
V	2011	ALL	Body	Rear HVAC/RSA																																								
V	2011	ALL	Body	Supplemental Inflatable Restraint																																								
V	2011	ALL	Body	Theft Deterrent Module																																								
V	2012	ALL	Powertrain	Engine Control Module																																								
V	2012	ALL	Powertrain	Fuel Pump Control Module																																								
V	2012	ALL	Powertrain	Rear Drive System																																								
V	2012	ALL	Powertrain	Transmission Control Module																																								
V	2012	ALL	Chassis	Electronic Brake Control Module																																								
V	2012	ALL	Body	Body Control Module																																								
V	2012	ALL	Body	Digital Radio Receiver																																								
V	2012	ALL	Body	Driver Door Switch				V																																				
V	2012	ALL	Body	Heated Seat Module																																								
V	2012	ALL	Body	HVAC Control Module Auto																																								
V	2012	ALL	Body	HVAC Control Module Manual																																								
V	2012	ALL	Body	Instrument Panel Cluster																																								
V	2012	ALL	Body	Lift Gate Module																																								
V	2012	ALL	Body	Park Assist Module																																								
V	2012	ALL	Body	Passenger Door Switch				V																																				
V	2012	ALL	Body	Passenger Presence System																																								
V	2012	ALL	Body	Radio																																								
V	2012	ALL	Body	Rear HVAC/RSA																																								
V	2012	ALL	Body	Supplemental Inflatable Restraint																																								
V	2012	ALL	Body	Theft Deterrent Module																																								
V	2013	ALL	Powertrain	Engine Control Module																																								
V	2013	ALL	Powertrain	Fuel Pump Control Module																																								
V	2013	ALL	Powertrain	Rear Drive System																																								
V	2013	ALL	Powertrain	Transmission Control Module																																								
V	2013	ALL	Chassis	Electronic Brake Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
V	2013	ALL	Body	Body Control Module																																								
V	2013	ALL	Body	Digital Radio Receiver																																								
V	2013	ALL	Body	Driver Door Switch				V																																				
V	2013	ALL	Body	Heated Seat Module																																								
V	2013	ALL	Body	HVAC Control Module Auto																																								
V	2013	ALL	Body	HVAC Control Module Manual																																								
V	2013	ALL	Body	Instrument Panel Cluster																																								
V	2013	ALL	Body	Left Side Object Detection Module																																								
V	2013	ALL	Body	Lift Gate Module																																								
V	2013	ALL	Body	Park Assist Module																																								
V	2013	ALL	Body	Passenger Door Switch				V																																				
V	2013	ALL	Body	Passenger Presence System																																								
V	2013	ALL	Body	Radio																																								
V	2013	ALL	Body	Rear HVAC/RSA																																								
V	2013	ALL	Body	Right Side Object Detection Module																																								
V	2013	ALL	Body	Supplemental Inflatable Restraint																																								
V	2013	ALL	Body	Theft Deterrent Module																																								
V	2014	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																								
V	2014	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
V	2014	Traverse	Powertrain	Chassis Control Module																																								
V	2014	Traverse	Powertrain	Rear Differential Clutch Control Module																																								
V	2014	Traverse	Chassis	Electronic Brake Control Module																																								
V	2014	Traverse	Body	Body Control Module Mechanical Liftgate																																								
V	2014	Traverse	Body	Body Control Module Power Liftgate (TB5)																																								
V	2014	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
V	2014	Traverse	Body	Passenger Presence Module																																								
V	2014	Traverse	Body	Instrument Cluster																																								
V	2014	Traverse	Body	Radio																																								
V	2014	Traverse	Body	Rear Audio Control Module																																								
V	2014	Traverse	Body	Digital Radio Receiver Control Module																																								
V	2014	Traverse	Body	Personal Audio Link Control Module																																								
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 9																																								
V	2014	Traverse	Body	Telematics Communication Interface Control Module Version 10																																								
V	2014	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																								
V	2014	Traverse	Body	HVAC Manual Control Single Zone (C67)																																								
V	2014	Traverse	Body	Driver Door Switch Panel Control Module																																								
V	2014	Traverse	Body	Passenger Door Switch Panel Control Module																																								
V	2014	Traverse	Body	Liftgate Control Module																																								
V	2014	Traverse	Body	Seat Memory Control Module																																								
V	2014	Traverse	Body	Front Seat Heating Control Module																																								
V	2014	Traverse	Body	Right Side Object Detection Control Module																																								
V	2014	Traverse	Body	Left Side Object Detection Control Module																																								
V	2014	Traverse	Body	Remote Control Door Lock Receiver																																								
V	2014	Traverse	Body	Parking Assist Control Module																																								
V	2014	Traverse	Body	Frontview Camera Module																																								
V	2014	Traverse	Body	Theft Deterrent Module																																								
V	2015	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																								
V	2015	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
V	2015	Traverse	Powertrain	Rear Differential Clutch Control Module																																								
V	2015	Traverse	Chassis	Electronic Brake Control Module																																								
V	2015	Traverse	Body	Body Control Module Mechanical Liftgate																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
V	2015	Traverse	Body	Body Control Module Power Liftgate (TB5)																																								
V	2015	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
V	2015	Traverse	Body	Passenger Presence Module																																								
V	2015	Traverse	Body	Instrument Cluster																																								
V	2015	Traverse	Body	Radio																																								
V	2015	Traverse	Body	Digital Radio Receiver Control Module																																								
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 9																																								
V	2015	Traverse	Body	Telematics Communication Interface Control Module Version 10																																								
V	2015	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																								
V	2015	Traverse	Body	HVAC Manual Control Single Zone (C67)																																								
V	2015	Traverse	Body	Liftgate Control Module																																								
V	2015	Traverse	Body	Seat Memory Control Module																																								
V	2015	Traverse	Body	Front Seat Heating Control Module																																								
V	2015	Traverse	Body	Right Side Object Detection Control Module																																								
V	2015	Traverse	Body	Left Side Object Detection Control Module																																								
V	2015	Traverse	Body	Remote Control Door Lock Receiver																																								
V	2015	Traverse	Body	Parking Assist Control Module																																								
V	2015	Traverse	Body	Frontview Camera Module																																								
V	2015	Traverse	Body	Theft Deterrent Module																																								
V	2016	Traverse	Powertrain	(D) 3.6L LLT Engine Control Module																																								
V	2016	Traverse	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
V	2016	Traverse	Powertrain	Rear Differential Clutch Control Module																																								
V	2016	Traverse	Chassis	Electronic Brake Control Module																																								
V	2016	Traverse	Body	Body Control Module Mechanical Liftgate																																								
V	2016	Traverse	Body	Body Control Module Power Liftgate (TB5)																																								
V	2016	Traverse	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
V	2016	Traverse	Body	Passenger Presence Module																																								
V	2016	Traverse	Body	Instrument Cluster																																								
V	2016	Traverse	Body	Radio																																								
V	2016	Traverse	Body	Rear Audio Control Module																																								
V	2016	Traverse	Body	Digital Radio Receiver Control Module																																								
V	2016	Traverse	Body	Personal Audio Link Control Module																																								
V	2016	Traverse	Body	Telematics Communication Interface Control Module																																								
V	2016	Traverse	Body	HVAC Auto Control Dual Zone (CJ2)																																								
V	2016	Traverse	Body	HVAC Manual Control Single Zone (C67)																																								
V	2016	Traverse	Body	Driver Door Switch Panel Control Module																																								
V	2016	Traverse	Body	Passenger Door Switch Panel Control Module																																								
V	2016	Traverse	Body	Liftgate Control Module																																								
V	2016	Traverse	Body	Seat Memory Control Module																																								
V	2016	Traverse	Body	Front Seat Heating Control Module																																								
V	2016	Traverse	Body	Right Side Object Detection Control Module																																								
V	2016	Traverse	Body	Left Side Object Detection Control Module																																								
V	2016	Traverse	Body	Remote Control Door Lock Receiver																																								
V	2016	Traverse	Body	Parking Assist Control Module																																								
V	2016	Traverse	Body	Frontview Camera Module																																								
V	2016	Traverse	Body	Theft Deterrent Module																																								
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																								
A	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																								
A	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																								
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
A	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
A	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																								
A	2011	Orlando	Powertrain	Fuel Injector Control Module																																								
A	2011	Orlando	Chassis	Electronic Brake Control Module																																								
A	2011	Orlando	Chassis	Parking Brake Control Module																																								
A	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																								
A	2011	Orlando	Chassis	Power Steering Control Module																																								
A	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																								
A	2011	Orlando	Body	Body Control Module																																								
A	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
A	2011	Orlando	Body	Instrument Cluster																																								
A	2011	Orlando	Body	Trailer Interface Control Module																																								
A	2011	Orlando	Body	Radio																																								
A	2011	Orlando	Body	Multimedia Player Interface Module																																								
A	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																								
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																								
A	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																								
A	2011	Orlando	Body	Keyless Entry Control Module																																								
A	2011	Orlando	Body	Parking Assist Control Module																																								
A	2011	Orlando	Body	Steering Column Lock Control Module																																								
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																								
A	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																								
A	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																								
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																								
A	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																								
A	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																								
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
A	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
A	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																								
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																								
A	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																								
A	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																								
A	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																								
A	2012	Orlando	Powertrain	Fuel Injector Control Module																																								
A	2012	Orlando	Chassis	Electronic Brake Control Module																																								
A	2012	Orlando	Chassis	Parking Brake Control Module																																								
A	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																								
A	2012	Orlando	Chassis	Power Steering Control Module																																								
A	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																								
A	2012	Orlando	Body	Body Control Module																																								
A	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
A	2012	Orlando	Body	Instrument Cluster																																								
A	2012	Orlando	Body	Trailer Interface Control Module																																								
A	2012	Orlando	Body	Radio																																								
A	2012	Orlando	Body	Multimedia Player Interface Module																																								
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																								
A	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																								
A	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																								
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																								
A	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																								
A	2012	Orlando	Body	Keyless Entry Control Module																																								
A	2012	Orlando	Body	Parking Assist Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
A	2012	Orlando	Body	Steering Column Lock Control Module																																								
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																								
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																								
A	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																								
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																								
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																								
A	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																								
A	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																								
A	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																								
A	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																								
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
A	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
A	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																								
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																								
A	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																								
A	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																								
A	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																								
A	2013	Orlando	Chassis	Electronic Brake Control Module																																								
A	2013	Orlando	Chassis	Parking Brake Control Module																																								
A	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																								
A	2013	Orlando	Chassis	Power Steering Control Module																																								
A	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																								
A	2013	Orlando	Body	Body Control Module																																								
A	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
A	2013	Orlando	Body	Instrument Cluster																																								
A	2013	Orlando	Body	Radio																																								
A	2013	Orlando	Body	Digital Radio Receiver Control Module																																								
A	2013	Orlando	Body	Multimedia Player Interface Module																																								
A	2013	Orlando	Body	Mobile Telephone Control Module																																								
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																								
A	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																								
A	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																								
A	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																								
A	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																								
A	2013	Orlando	Body	Front Seat Heating Control Module																																								
A	2013	Orlando	Body	Keyless Entry Control Module																																								
A	2013	Orlando	Body	Parking Assist Control Module																																								
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																								
A	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																								
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																								
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																								
A	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																								
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																								
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																								
A	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																								
A	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																								
A	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																								
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
A	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
A	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																								
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																								
A	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																								
A	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
A	2014	Orlando	Powertrain	Fuel Injector Control Module																																								
A	2014	Orlando	Chassis	Electronic Brake Control Module																																								
A	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																								
A	2014	Orlando	Chassis	Power Steering Control Module																																								
A	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																								
A	2014	Orlando	Body	Body Control Module																																								
A	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
A	2014	Orlando	Body	Instrument Cluster																																								
A	2014	Orlando	Body	Radio																																								
A	2014	Orlando	Body	Digital Radio Receiver Control Module																																								
A	2014	Orlando	Body	Multimedia Player Interface Module																																								
A	2014	Orlando	Body	Mobile Telephone Control Module																																								
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																								
A	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																								
A	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																								
A	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																								
A	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																								
A	2014	Orlando	Body	Front Seat Heating Control Module																																								
A	2014	Orlando	Body	Rear Seat Heating Control Module																																								
A	2014	Orlando	Body	Keyless Entry Control Module																																								
A	2014	Orlando	Body	Parking Assist Control Module																																								
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
A	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
A	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																								
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																								
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																								
A	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																								
A	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																								
A	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																								
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
A	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
A	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																								
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																								
A	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																								
A	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
A	2015	Orlando	Powertrain	Fuel Injector Control Module																																								
A	2015	Orlando	Chassis	Electronic Brake Control Module																																								
A	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																								
A	2015	Orlando	Chassis	Power Steering Control Module																																								
A	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																								
A	2015	Orlando	Body	Body Control Module																																								
A	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
A	2015	Orlando	Body	Instrument Cluster																																								
A	2015	Orlando	Body	Radio																																								
A	2015	Orlando	Body	Digital Radio Receiver Control Module																																								
A	2015	Orlando	Body	Mobile Telephone Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
A	2015	Orlando	Body	Telematics Communication Interface Control Module																																								
A	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																								
A	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																								
A	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																								
A	2015	Orlando	Body	Front Seat Heating Control Module																																								
A	2015	Orlando	Body	Rear Seat Heating Control Module																																								
A	2015	Orlando	Body	Keyless Entry Control Module																																								
A	2015	Orlando	Body	Parking Assist Control Module																																								
A	2015	Orlando	Body	Frontview Camera Module																																								
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
A	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
A	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																								
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																								
A	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																								
A	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																								
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																								
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																								
A	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
A	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																								
A	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																								
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
A	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
A	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																								
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																								
A	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																								
A	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
A	2016	Orlando	Powertrain	Fuel Injector Control Module																																								
A	2016	Orlando	Chassis	Electronic Brake Control Module																																								
A	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																								
A	2016	Orlando	Chassis	Power Steering Control Module																																								
A	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																								
A	2016	Orlando	Body	Body Control Module																																								
A	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
A	2016	Orlando	Body	Instrument Cluster																																								
A	2016	Orlando	Body	Radio																																								
A	2016	Orlando	Body	Digital Radio Receiver Control Module																																								
A	2016	Orlando	Body	Multimedia Player Interface Module																																								
A	2016	Orlando	Body	Mobile Telephone Control Module																																								
A	2016	Orlando	Body	Telematics Communication Interface Control Module																																								
A	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																								
A	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																								
A	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																								
A	2016	Orlando	Body	Front Seat Heating Control Module																																								
A	2016	Orlando	Body	Rear Seat Heating Control Module																																								
A	2016	Orlando	Body	Keyless Entry Control Module																																								
A	2016	Orlando	Body	Parking Assist Control Module																																								
A	2016	Orlando	Body	Frontview Camera Module																																								
B	2011	Tavera	Powertrain	2.0L LKM Engine Control Module																																								
B	2012	Tavera	Powertrain	2.0L LKM Engine Control Module																																								
B	2013	Tavera	Powertrain	2.0L LKM Engine Control Module																																								
B	2014	Tavera	Powertrain	2.0L LKM Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
B	2015	Tavera	Powertrain	2.0L LKM Engine Control Module																																								
B	2016	Tavera	Powertrain	2.0L LKM Engine Control Module																																								
C	2009	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																								
C	2009	N200	Chassis	Electronic Brake Control Module																																								
C	2009	N200	Body	Supplemental Inflatable Restraint																																								
C	2009	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																								
C	2009	N300	Chassis	Electronic Brake Control Module																																								
C	2009	N300	Body	Supplemental Inflatable Restraint																																								
C	2010	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																								
C	2010	N200	Chassis	Electronic Brake Control Module																																								
C	2010	N200	Body	Supplemental Inflatable Restraint																																								
C	2010	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																								
C	2010	N300	Chassis	Electronic Brake Control Module																																								
C	2010	N300	Body	Supplemental Inflatable Restraint																																								
C	2011	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																								
C	2011	N200	Chassis	Electronic Brake Control Module																																								
C	2011	N200	Body	Supplemental Inflatable Restraint																																								
C	2011	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																								
C	2011	N300	Chassis	Electronic Brake Control Module																																								
C	2011	N300	Body	Supplemental Inflatable Restraint																																								
C	2012	N200	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																								
C	2012	N200	Chassis	Electronic Brake Control Module																																								
C	2012	N200	Body	Supplemental Inflatable Restraint																																								
C	2012	N300	Powertrain	(A)1.2L L4 LAQ Engine Control Module																																								
C	2012	N300	Chassis	Electronic Brake Control Module																																								
C	2012	N300	Body	Supplemental Inflatable Restraint																																								
C	2013	N300	Powertrain	1.2L LAQ Engine Control Module																																								
C	2013	N300	Chassis	Electronic Brake Control Module																																								
C	2013	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2014	N300	Powertrain	1.2L LAQ Engine Control Module																																								
C	2014	N300	Powertrain	1.5L L3C Engine Control Module																																								
C	2014	N300	Chassis	Electronic Brake Control Module																																								
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2014	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2015	Max	Powertrain	1.2L LAQ Engine Control Module																																								
C	2015	Max	Powertrain	1.2L LD6 Engine Control Module																																								
C	2015	Max	Powertrain	1.5L L3C Engine Control Module																																								
C	2015	Max	Chassis	Electronic Brake Control Module																																								
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2015	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2015	Move	Powertrain	1.2L LAQ Engine Control Module																																								
C	2015	Move	Powertrain	1.2L LD6 Engine Control Module																																								
C	2015	Move	Powertrain	1.5L L3C Engine Control Module																																								
C	2015	Move	Chassis	Electronic Brake Control Module																																								
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2015	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
C	2015	N300	Powertrain	1.2L LAQ Engine Control Module																																								
C	2015	N300	Powertrain	1.2L LD6 Engine Control Module																																								
C	2015	N300	Powertrain	1.5L L3C Engine Control Module																																								
C	2015	N300	Chassis	Electronic Brake Control Module																																								
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2015	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																									
C	2016	Max	Powertrain	1.2L LAQ Engine Control Module																																									
C	2016	Max	Powertrain	1.2L LD6 Engine Control Module																																									
C	2016	Max	Powertrain	1.5L L3C Engine Control Module																																									
C	2016	Max	Chassis	Electronic Brake Control Module																																									
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																									
C	2016	Max	Body	Inflatable Restraint Sensing and Diagnostic Module																																									
C	2016	Move	Powertrain	1.2L LAQ Engine Control Module																																									
C	2016	Move	Powertrain	1.2L LD6 Engine Control Module																																									
C	2016	Move	Powertrain	1.5L L3C Engine Control Module																																									
C	2016	Move	Chassis	Electronic Brake Control Module																																									
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																									
C	2016	Move	Body	Inflatable Restraint Sensing and Diagnostic Module																																									
C	2016	N300	Powertrain	1.2L LAQ Engine Control Module																																									
C	2016	N300	Powertrain	1.2L LD6 Engine Control Module																																									
C	2016	N300	Powertrain	1.5L L3C Engine Control Module																																									
C	2016	N300	Chassis	Electronic Brake Control Module																																									
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																									
C	2016	N300	Body	Inflatable Restraint Sensing and Diagnostic Module																																									
M	2015	City Express	Powertrain	2.0L L0A Engine Control Module																																									
M	2015	City Express	Powertrain	2.0L L0A Transmission Control Module																																									
M	2015	City Express	Chassis	Electronic Brake Control Module																																									
M	2015	City Express	Chassis	Power Steering Control Module																																									
M	2015	City Express	Body	Body Control Module																												V	V												
M	2015	City Express	Body	Underhood Fuse Block																																									
M	2015	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																									
M	2015	City Express	Body	Instrument Cluster																																									
M	2015	City Express	Body	Tire Pressure Indicator Module																														V											
M	2015	City Express	Body	Radio																																									
M	2016	City Express	Powertrain	(3) 2.0L L0A Engine Control Module																																									
M	2016	City Express	Powertrain	(3) 2.0L L0A Transmission Control Module																																									
M	2016	City Express	Chassis	Electronic Brake Control Module																																									
M	2016	City Express	Chassis	Power Steering Control Module																																									
M	2016	City Express	Body	Body Control Module																												V	V												
M	2016	City Express	Body	Underhood Fuse Block																																									
M	2016	City Express	Body	Inflatable Restraint Sensing and Diagnostic Module																																									
M	2016	City Express	Body	Instrument Cluster																																									
M	2016	City Express	Body	Tire Pressure Indicator Module																														V											
M	2016	City Express	Body	Radio																																									
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																									
P	2011	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																									
P	2011	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																									
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																									
P	2011	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																									
P	2011	Orlando	Powertrain	2.0L LNP Transmission Control Module																																									
P	2011	Orlando	Powertrain	Fuel Injector Control Module																																									
P	2011	Orlando	Chassis	Electronic Brake Control Module																																									
P	2011	Orlando	Chassis	Parking Brake Control Module																																									
P	2011	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																									
P	2011	Orlando	Chassis	Power Steering Control Module																																									
P	2011	Orlando	Chassis	Steering Wheel Angle Sensor Module																																									

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
P	2011	Orlando	Body	Body Control Module																																								
P	2011	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
P	2011	Orlando	Body	Instrument Cluster																																								
P	2011	Orlando	Body	Trailer Interface Control Module																																								
P	2011	Orlando	Body	Radio																																								
P	2011	Orlando	Body	Multimedia Player Interface Module																																								
P	2011	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																								
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																								
P	2011	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																								
P	2011	Orlando	Body	Keyless Entry Control Module																																								
P	2011	Orlando	Body	Parking Assist Control Module																																								
P	2011	Orlando	Body	Steering Column Lock Control Module																																								
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Automatic Transmission																																								
P	2012	Orlando	Powertrain	1.8L 2H0 Engine Control Module Manual Transmission																																								
P	2012	Orlando	Powertrain	1.8L 2H0 Transmission Control Module																																								
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																								
P	2012	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																								
P	2012	Orlando	Powertrain	2.0L LBN Transmission Control Module																																								
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
P	2012	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
P	2012	Orlando	Powertrain	2.0L LNP Transmission Control Module																																								
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Automatic Transmission																																								
P	2012	Orlando	Powertrain	2.4L LAF Engine Control Module Manual Transmission																																								
P	2012	Orlando	Powertrain	2.4L LAF Transmission Control Module																																								
P	2012	Orlando	Powertrain	2.4L LAF Fuel Pump Control Module																																								
P	2012	Orlando	Powertrain	Fuel Injector Control Module																																								
P	2012	Orlando	Chassis	Electronic Brake Control Module																																								
P	2012	Orlando	Chassis	Parking Brake Control Module																																								
P	2012	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																								
P	2012	Orlando	Chassis	Power Steering Control Module																																								
P	2012	Orlando	Chassis	Steering Wheel Angle Sensor Module																																								
P	2012	Orlando	Body	Body Control Module																																								
P	2012	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
P	2012	Orlando	Body	Instrument Cluster																																								
P	2012	Orlando	Body	Trailer Interface Control Module																																								
P	2012	Orlando	Body	Radio																																								
P	2012	Orlando	Body	Multimedia Player Interface Module																																								
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 9																																								
P	2012	Orlando	Body	Telematics Communication Interface Control Module Version 10																																								
P	2012	Orlando	Body	Remote Heater and Air Conditioning Auto Single (C68)																																								
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Heater Only (C42)																																								
P	2012	Orlando	Body	Remote Heater and Air Conditioning Manual Single (C67)																																								
P	2012	Orlando	Body	Keyless Entry Control Module																																								
P	2012	Orlando	Body	Parking Assist Control Module																																								
P	2012	Orlando	Body	Steering Column Lock Control Module																																								
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																								
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																								
P	2013	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																								
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																								
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																								
P	2013	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																								
P	2013	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																								
P	2013	Orlando	Powertrain	2.0L LBN Transmission Control Module																																								
P	2013	Orlando	Powertrain	2.0L LBN Fuel Injector Control Module																																								
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
P	2013	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
P	2013	Orlando	Powertrain	2.0L LNP Transmission Control Module																																								
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Automatic Transmission																																								
P	2013	Orlando	Powertrain	(T) 2.4L LEA Engine Control Module Manual Transmission																																								
P	2013	Orlando	Powertrain	(T) 2.4L LEA Transmission Control Module																																								
P	2013	Orlando	Powertrain	(T) 2.4L LEA Fuel Pump Control Module																																								
P	2013	Orlando	Chassis	Electronic Brake Control Module																																								
P	2013	Orlando	Chassis	Parking Brake Control Module																																								
P	2013	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																								
P	2013	Orlando	Chassis	Power Steering Control Module																																								
P	2013	Orlando	Chassis	Steering Wheel Angle Sensor Module																																								
P	2013	Orlando	Body	Body Control Module																																								
P	2013	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
P	2013	Orlando	Body	Instrument Cluster																																								
P	2013	Orlando	Body	Radio																																								
P	2013	Orlando	Body	Digital Radio Receiver Control Module																																								
P	2013	Orlando	Body	Multimedia Player Interface Module																																								
P	2013	Orlando	Body	Mobile Telephone Control Module																																								
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 9																																								
P	2013	Orlando	Body	Telematics Communication Interface Control Module Version 10																																								
P	2013	Orlando	Body	HVAC Control Module Auto Single (C68)																																								
P	2013	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																								
P	2013	Orlando	Body	HVAC Control Module Manual Single (C67)																																								
P	2013	Orlando	Body	Front Seat Heating Control Module																																								
P	2013	Orlando	Body	Keyless Entry Control Module																																								
P	2013	Orlando	Body	Parking Assist Control Module																																								
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Automatic Transmission																																								
P	2014	Orlando	Powertrain	1.4L LDD Engine Control Module Manual Transmission																																								
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Automatic Transmission																																								
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Engine Control Module Manual Transmission																																								
P	2014	Orlando	Powertrain	(8) 1.4L LUJ Transmission Control Module																																								
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																								
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																								
P	2014	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																								
P	2014	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																								
P	2014	Orlando	Powertrain	2.0L LBN Transmission Control Module																																								
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
P	2014	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
P	2014	Orlando	Powertrain	2.0L LNP Transmission Control Module																																								
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																								
P	2014	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																								
P	2014	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
P	2014	Orlando	Powertrain	Fuel Injector Control Module																																								
P	2014	Orlando	Chassis	Electronic Brake Control Module																																								
P	2014	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
P	2014	Orlando	Chassis	Power Steering Control Module																																								
P	2014	Orlando	Chassis	Steering Wheel Angle Sensor Module																																								
P	2014	Orlando	Body	Body Control Module																																								
P	2014	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
P	2014	Orlando	Body	Instrument Cluster																																								
P	2014	Orlando	Body	Radio																																								
P	2014	Orlando	Body	Digital Radio Receiver Control Module																																								
P	2014	Orlando	Body	Multimedia Player Interface Module																																								
P	2014	Orlando	Body	Mobile Telephone Control Module																																								
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 9																																								
P	2014	Orlando	Body	Telematics Communication Interface Control Module Version 10																																								
P	2014	Orlando	Body	HVAC Control Module Auto Single (C68)																																								
P	2014	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																								
P	2014	Orlando	Body	HVAC Control Module Manual Single (C67)																																								
P	2014	Orlando	Body	Front Seat Heating Control Module																																								
P	2014	Orlando	Body	Rear Seat Heating Control Module																																								
P	2014	Orlando	Body	Keyless Entry Control Module																																								
P	2014	Orlando	Body	Parking Assist Control Module																																								
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
P	2015	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
P	2015	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																								
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																								
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																								
P	2015	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Automatic Transmission																																								
P	2015	Orlando	Powertrain	2.0L LBN Engine Control Module Manual Transmission																																								
P	2015	Orlando	Powertrain	2.0L LBN Transmission Control Module																																								
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
P	2015	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
P	2015	Orlando	Powertrain	2.0L LNP Transmission Control Module																																								
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																								
P	2015	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																								
P	2015	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
P	2015	Orlando	Powertrain	Fuel Injector Control Module																																								
P	2015	Orlando	Chassis	Electronic Brake Control Module																																								
P	2015	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																								
P	2015	Orlando	Chassis	Power Steering Control Module																																								
P	2015	Orlando	Chassis	Steering Wheel Angle Sensor Module																																								
P	2015	Orlando	Body	Body Control Module																																								
P	2015	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
P	2015	Orlando	Body	Instrument Cluster																																								
P	2015	Orlando	Body	Radio																																								
P	2015	Orlando	Body	Digital Radio Receiver Control Module																																								
P	2015	Orlando	Body	Mobile Telephone Control Module																																								
P	2015	Orlando	Body	Telematics Communication Interface Control Module																																								
P	2015	Orlando	Body	HVAC Control Module Auto Single (C68)																																								
P	2015	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																								
P	2015	Orlando	Body	HVAC Control Module Manual Single (C67)																																								
P	2015	Orlando	Body	Front Seat Heating Control Module																																								
P	2015	Orlando	Body	Rear Seat Heating Control Module																																								
P	2015	Orlando	Body	Keyless Entry Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
P	2015	Orlando	Body	Parking Assist Control Module																																								
P	2015	Orlando	Body	Frontview Camera Module																																								
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Automatic Transmission																																								
P	2016	Orlando	Powertrain	1.4L LUJ Engine Control Module Manual Transmission																																								
P	2016	Orlando	Powertrain	1.4L LUJ Transmission Control Module																																								
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Automatic Transmission																																								
P	2016	Orlando	Powertrain	1.6L LVL Engine Control Module Manual Transmission																																								
P	2016	Orlando	Powertrain	1.6L LVL Transmission Control Module																																								
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Automatic Transmission																																								
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Engine Control Module Manual Transmission																																								
P	2016	Orlando	Powertrain	(E) 1.8L 2H0 Transmission Control Module																																								
P	2016	Orlando	Powertrain	2.0L LBN Engine Control Module																																								
P	2016	Orlando	Powertrain	2.0L LBN Transmission Control Module																																								
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Automatic Transmission																																								
P	2016	Orlando	Powertrain	2.0L LNP Engine Control Module Manual Transmission																																								
P	2016	Orlando	Powertrain	2.0L LNP Transmission Control Module																																								
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Automatic Transmission																																								
P	2016	Orlando	Powertrain	(K) 2.4L LEA Engine Control Module Manual Transmission																																								
P	2016	Orlando	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
P	2016	Orlando	Powertrain	Fuel Injector Control Module																																								
P	2016	Orlando	Chassis	Electronic Brake Control Module																																								
P	2016	Orlando	Chassis	Multi-Axis Acceleration Sensor Module																																								
P	2016	Orlando	Chassis	Power Steering Control Module																																								
P	2016	Orlando	Chassis	Steering Wheel Angle Sensor Module																																								
P	2016	Orlando	Body	Body Control Module																																								
P	2016	Orlando	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
P	2016	Orlando	Body	Instrument Cluster																																								
P	2016	Orlando	Body	Radio																																								
P	2016	Orlando	Body	Digital Radio Receiver Control Module																																								
P	2016	Orlando	Body	Multimedia Player Interface Module																																								
P	2016	Orlando	Body	Mobile Telephone Control Module																																								
P	2016	Orlando	Body	Telematics Communication Interface Control Module																																								
P	2016	Orlando	Body	HVAC Control Module Auto Single (C68)																																								
P	2016	Orlando	Body	HVAC Control Module Manual Heater Only (C42)																																								
P	2016	Orlando	Body	HVAC Control Module Manual Single (C67)																																								
P	2016	Orlando	Body	Front Seat Heating Control Module																																								
P	2016	Orlando	Body	Rear Seat Heating Control Module																																								
P	2016	Orlando	Body	Keyless Entry Control Module																																								
P	2016	Orlando	Body	Parking Assist Control Module																																								
P	2016	Orlando	Body	Frontview Camera Module																																								
U	2004	ALL	Powertrain	Engine Control Module																																								
U	2004	ALL	Powertrain	Transmission Control Module																																								
U	2004	ALL	Body	Digital Radio Receiver																																								
U	2004	ALL	Body	Driver Information Center																																								
U	2004	ALL	Body	Instrument Panel Cluster																																								
U	2004	ALL	Body	Radio																																								
U	2004	ALL	Body	Supplemental Inflatable Restraint																																								
U	2004	ALL	Body	Vehicle Theft Deterrent																																								
U	2005	ALL	Powertrain	Engine Control Module																					V	V																		
U	2005	ALL	Powertrain	Transmission Control Module																																								
U	2005	ALL	Chassis	Electronic Brake Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
U	2005	ALL	Body	Body Control Module																															V									
U	2005	ALL	Body	Disc Player and Video																																								
U	2005	ALL	Body	Digital Radio Receiver																																								
U	2005	ALL	Body	HVAC Control Module																																								
U	2005	ALL	Body	Instrument Panel Cluster																																V								
U	2005	ALL	Body	Left Power Sliding Door Module																																								
U	2005	ALL	Body	Mobile Digital Media																																								
U	2005	ALL	Body	Navigation Radio																																								
U	2005	ALL	Body	Navigation Radio																																								
U	2005	ALL	Body	Radio																																	V	V						
U	2005	ALL	Body	Right Power Sliding Door Module																																								
U	2005	ALL	Body	Supplemental Inflatable Restraint																																								
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																					V	V																			
U	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																								
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																			V					
U	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																								
U	2006	ALL	Chassis	Electronic Brake Control Module																																								
U	2006	ALL	Body	Body Control Module																															V									
U	2006	ALL	Body	Disc Player and Video																																								
U	2006	ALL	Body	Digital Radio Receiver																																								
U	2006	ALL	Body	HVAC Control Module																																								
U	2006	ALL	Body	Instrument Panel Cluster																																								
U	2006	ALL	Body	Left Power Sliding Door Module																																								
U	2006	ALL	Body	Mobile Digital Media																																								
U	2006	ALL	Body	Navigation Radio																																								
U	2006	ALL	Body	Navigation Radio																																								
U	2006	ALL	Body	Radio																																	V	V						
U	2006	ALL	Body	Right Power Sliding Door Module																																								
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																								
U	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																								
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																								
U	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																								
U	2007	ALL	Chassis	Electronic Brake Control Module																																								
U	2007	ALL	Body	Body Control Module																															V									
U	2007	ALL	Body	Digital Radio Receiver																																								
U	2007	ALL	Body	Disc Player and Video Display																																								
U	2007	ALL	Body	HVAC Control Module																																								
U	2007	ALL	Body	Left Power Sliding Door Module																																								
U	2007	ALL	Body	Mobile Digital Media																																								
U	2007	ALL	Body	Radio																																	V	V						
U	2007	ALL	Body	Navigation Radio																																								
U	2007	ALL	Body	Right Power Sliding Door Module																																								
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																								
U	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																								
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																								
U	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																								
U	2008	ALL	Chassis	Electronic Brake Control Module																																								
U	2008	ALL	Body	Body Control Module																															V									
U	2008	ALL	Body	Digital Radio Receiver																																								
U	2008	ALL	Body	Disc Player and Video Display																																								
U	2008	ALL	Body	C60 Single Zone HVAC Manual																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
U	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																									
U	2008	ALL	Body	Left Power Sliding Door Module																																									
U	2008	ALL	Body	Radio																																	V	V							
U	2008	ALL	Body	Navigation Radio																																									
U	2008	ALL	Body	Remote Control Door Lock Receiver													V																							V					
U	2008	ALL	Body	Right Power Sliding Door Module																																									
U	2009	ALL	Powertrain	Engine Control Module																																									
U	2009	ALL	Powertrain	Transmission Control Module																																									
U	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																									
U	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																									
U	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																									
U	2009	ALL	Body	Body Control Module																														V											
U	2009	ALL	Body	Digital Radio Receiver																																									
U	2009	ALL	Body	Disc Player and Video Display																																									
U	2009	ALL	Body	C60 Single Zone HVAC Manual																																									
U	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																									
U	2009	ALL	Body	Instrument Panel Cluster																																									
U	2009	ALL	Body	Left Power Sliding Door Module																																									
U	2009	ALL	Body	Radio																																	V	V							
U	2009	ALL	Body	Remote Control Door Lock Receiver													V																							V					
U	2009	ALL	Body	Right Power Sliding Door Module																																									
V	2004	ALL	Powertrain	Engine Data Display																																									
V	2004	ALL	Powertrain	Transmission Data Display																																					V				
V	2004	ALL	Body	Digital Radio Receiver																																									
V	2004	ALL	Body	Driver Information Center																																									
V	2004	ALL	Body	Instrument Panel Cluster																																									
V	2004	ALL	Body	Radio																																									
V	2004	ALL	Body	Supplemental Inflatable Restraint																																									
V	2004	ALL	Body	Vehicle Theft Deterrent																																									
V	2005	Venture	Powertrain	Engine Control Module																																									
V	2005	Venture	Powertrain	Transmission Control Module																																									
V	2005	Venture	Body	Digital Radio Receiver																																									
V	2005	Venture	Body	Driver Information Center																																									
V	2005	Venture	Body	Instrument Panel Cluster																																									
V	2005	Venture	Body	Radio																																						V	V	V
V	2005	Venture	Body	Supplemental Inflatable Restraint																																									
V	2005	Venture	Body	Vehicle Theft Deterrent																																									
V	2005	Uplander	Powertrain	Engine Control Module																					V	V																			
V	2005	Uplander	Powertrain	Transmission Control Module																																									
V	2005	Uplander	Chassis	Electronic Brake Control Module																																									
V	2005	Uplander	Body	Body Control Module																														V											
V	2005	Uplander	Body	Disc Player and Video																																									
V	2005	Uplander	Body	Digital Radio Receiver																																									
V	2005	Uplander	Body	HVAC Control Module																																									
V	2005	Uplander	Body	Instrument Panel Cluster																																V									
V	2005	Uplander	Body	Left Power Sliding Door Module																																									
V	2005	Uplander	Body	Mobile Digital Media																																									
V	2005	Uplander	Body	Navigation Radio																																									
V	2005	Uplander	Body	Navigation Radio																																									
V	2005	Uplander	Body	Radio																																	V	V							
V	2005	Uplander	Body	Right Power Sliding Door Module																																									

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
V	2005	Uplander	Body	Supplemental Inflatable Restraint																																									
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																					V	V																			
V	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																									
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Engine Control Module																																		V							
V	2006	ALL	Powertrain	(1) 3.9L V6 LZ9 Transmission Control Module																																									
V	2006	ALL	Chassis	Electronic Brake Control Module																																									
V	2006	ALL	Body	Body Control Module																														V											
V	2006	ALL	Body	Disc Player and Video																																									
V	2006	ALL	Body	Digital Radio Receiver																																									
V	2006	ALL	Body	HVAC Control Module																																									
V	2006	ALL	Body	Instrument Panel Cluster																																									
V	2006	ALL	Body	Left Power Sliding Door Module																																									
V	2006	ALL	Body	Mobile Digital Media																																									
V	2006	ALL	Body	Navigation Radio																																									
V	2006	ALL	Body	Navigation Radio																																									
V	2006	ALL	Body	Radio																																	V	V							
V	2006	ALL	Body	Right Power Sliding Door Module																																									
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																									
V	2007	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																									
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																									
V	2007	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																									
V	2007	ALL	Chassis	Electronic Brake Control Module																																									
V	2007	ALL	Body	Body Control Module																														V											
V	2007	ALL	Body	Digital Radio Receiver																																									
V	2007	ALL	Body	Disc Player and Video Display																																									
V	2007	ALL	Body	HVAC Control Module																																									
V	2007	ALL	Body	Left Power Sliding Door Module																																									
V	2007	ALL	Body	Mobile Digital Media																																									
V	2007	ALL	Body	Radio																																	V	V							
V	2007	ALL	Body	Navigation Radio																																									
V	2007	ALL	Body	Right Power Sliding Door Module																																									
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Engine Control Module																																									
V	2008	ALL	Powertrain	(W)3.9L V6 LGD Transmission Control Module																																									
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Engine Control Module																																									
V	2008	ALL	Powertrain	(1)3.9L V6 LZ9 Transmission Control Module																																									
V	2008	ALL	Chassis	Electronic Brake Control Module																																									
V	2008	ALL	Body	Body Control Module																														V											
V	2008	ALL	Body	Digital Radio Receiver																																									
V	2008	ALL	Body	Disc Player and Video Display																																									
V	2008	ALL	Body	C60 Single Zone HVAC Manual																																									
V	2008	ALL	Body	CJ3 Dual Zone HVAC Manual																																									
V	2008	ALL	Body	Left Power Sliding Door Module																																									
V	2008	ALL	Body	Radio																																	V	V							
V	2008	ALL	Body	Navigation Radio																																									
V	2008	ALL	Body	Remote Control Door Lock Receiver													V																							V					
V	2008	ALL	Body	Right Power Sliding Door Module																																									
V	2009	ALL	Powertrain	Engine Control Module																																									
V	2009	ALL	Powertrain	Transmission Control Module																																									
V	2009	ALL	Chassis	DBC7 C2 ABS TCS VSES EBCM																																									
V	2009	ALL	Chassis	DBC7 C2 ABS EBCM																																									
V	2009	ALL	Chassis	DBC7 C2 ABS TCS EBCM																																									

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
V	2009	ALL	Body	Body Control Module																															V									
V	2009	ALL	Body	Digital Radio Receiver																																								
V	2009	ALL	Body	Disc Player and Video Display																																								
V	2009	ALL	Body	C60 Single Zone HVAC Manual																																								
V	2009	ALL	Body	CJ3 Dual Zone HVAC Manual																																								
V	2009	ALL	Body	Driver Information Center Instrument Panel Cluster																																								
V	2009	ALL	Body	Not Driver Information Center Instrument Panel Cluster																																								
V	2009	ALL	Body	Left Power Sliding Door Module																																								
V	2009	ALL	Body	Radio																																V	V							
V	2009	ALL	Body	Remote Control Door Lock Receiver													V																						V					
V	2009	ALL	Body	Right Power Sliding Door Module																																								
X	2004	ALL	Powertrain	Engine Control Module																																								
X	2004	ALL	Powertrain	Transmission Control Module																																								
X	2004	ALL	Body	Digital Radio Receiver																																								
X	2004	ALL	Body	Driver Information Center																																								
X	2004	ALL	Body	Instrument Panel Cluster																																								
X	2004	ALL	Body	Radio																																								
X	2004	ALL	Body	Supplemental Inflatable Restraint																																								
X	2004	ALL	Body	Vehicle Theft Deterrent																																								
X	2005	ALL	Powertrain	Engine Control Module																					V	V																		
X	2005	ALL	Powertrain	Transmission Control Module																																				V				
X	2005	ALL	Chassis	Electronic Brake Control Module																																								
X	2005	ALL	Body	Body Control Module																															V									
X	2005	ALL	Body	Disc Player and Video																																								
X	2005	ALL	Body	Digital Radio Receiver																																								
X	2005	ALL	Body	HVAC Control Module																																								
X	2005	ALL	Body	Instrument Panel Cluster																																V								
X	2005	ALL	Body	Left Power Sliding Door Module																																								
X	2005	ALL	Body	Mobile Digital Media																																								
X	2005	ALL	Body	Navigation Radio																																								
X	2005	ALL	Body	Navigation Radio																																								
X	2005	ALL	Body	Radio																																V	V							
X	2005	ALL	Body	Right Power Sliding Door Module																																								
X	2005	ALL	Body	Supplemental Inflatable Restraint																																								
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Engine Control Module																					V	V																		
X	2006	ALL	Powertrain	(L) 3.5L V6 LX9 Transmission Control Module																																				V				
X	2006	ALL	Chassis	Electronic Brake Control Module																																								
X	2006	ALL	Body	Body Control Module																															V									
X	2006	ALL	Body	Disc Player and Video																																								
X	2006	ALL	Body	Digital Radio Receiver																																								
X	2006	ALL	Body	HVAC Control Module																																								
X	2006	ALL	Body	Instrument Panel Cluster																																								
X	2006	ALL	Body	Left Power Sliding Door Module																																								
X	2006	ALL	Body	Mobile Digital Media																																								
X	2006	ALL	Body	Navigation Radio																																								
X	2006	ALL	Body	Navigation Radio																																								
X	2006	ALL	Body	Radio																																V	V							
X	2006	ALL	Body	Right Power Sliding Door Module																																								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM	V	V										V	V				V	V		V	V							V													V															
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM		V																		V																																				
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM		V																		V																																				
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM		V																		V																																				
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM	V	V																		V										V	V																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V	V		V	V							V													V														
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V										V	V																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V	V		V	V							V													V														
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V										V	V																								
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V														
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V										V	V																								
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																								
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module	V	V										V					V			V								V													V														
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module	V	V																		V										V	V																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module	V	V										V	V				V			V	V							V													V														
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600	V	V																		V										V	V																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600	V	V																		V										V	V																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V			V	V							V													V														
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V										V	V																								
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module	V	V																		V	V																																		
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module	V	V																		V										V	V	V																							
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V																		V																																			
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V										V	V	V																							
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed	V	V																		V										V	V																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed	V	V																		V										V	V	V																							
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW	V	V																		V																																				
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																			
C	2004	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																			
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)		V																		V																																				
C	2004	ALL	Chassis	ESC	V	V																		V	V																																			
C	2004	ALL	Chassis	Rear Wheel Steering	V	V																		V	V																																			
C	2004	ALL	Chassis	Tire Pressure Monitor	V	V																																																					
C	2004	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
C	2004	ALL	Chassis	VSES	V	V																		V	V																																			
C	2004	ALL	Body	Amplifier (Bose)	V	V																			V																																			
C	2004	ALL	Body	Body Control Module	V	V																		V	V																																			
C	2004	ALL	Body	CD Changer	V																																																						
C	2004	ALL	Body	Chime	V	V																		V	V																																			
C	2004	ALL	Body	Driver Door Module	V	V																		V	V																																			
C	2004	ALL	Body	Driver Seat Module	V	V																		V	V																																			
C	2004	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
C	2004	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																			
C	2004	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2004	ALL	Body	OnStar	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2004	ALL	Body	Passenger Door Module	V	V																		V	V																																			
C	2004	ALL	Body	Passenger Presence System																																																								
C	2004	ALL	Body	Radio Base	V	V																			V																																			
C	2004	ALL	Body	Radio Uplevel	V	V																			V																																			
C	2004	ALL	Body	Radio Navigation	V	V																		V																																			
C	2004	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
C	2004	ALL	Body	Rear HVAC	V	V																			V																																			
C	2004	ALL	Body	Rear Seat Audio	V	V																			V																																			
C	2004	ALL	Body	Rear Seat Entertainment	V																				V																																			
C	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
C	2004	ALL	Body	Vehicle Theft Deterrent	V	V																																																						
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM	V	V										V	V				V	V		V	V							V														V														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM		V																		V																																				
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM		V																		V																																				
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM		V																		V																																				
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM	V	V																		V										V	V																									
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V	V		V	V							V														V														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V										V	V																									
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V	V		V	V							V														V														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V										V	V																									
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V														
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V														V														
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V										V	V																									
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module	V	V										V	V				V	V		V	V							V														V														
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module	V	V																		V										V	V																									
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V														V														
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																									
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V	V		V	V							V														V														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																									
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module	V	V										V					V			V								V														V														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module	V	V										V	V				V			V	V							V														V														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600	V	V																		V										V	V																									
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600	V	V																		V										V	V																									
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V			V	V							V														V														
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V										V	V																									
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V																		V																																				
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V										V	V	V																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module	V	V										V	V				V	V		V	V							V														V														
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed	V	V																		V										V	V																									
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed	V	V																		V										V	V	V																								
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW	V	V																		V	V																																			
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW	V	V																		V																																				
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																			
C	2005	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																			
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)		V																		V																																				
C	2005	ALL	Chassis	ESC	V	V																		V	V																																			
C	2005	ALL	Chassis	Rear Wheel Steering	V	V																		V	V																																			
C	2005	ALL	Chassis	Tire Pressure Monitor	V	V																																																					
C	2005	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
C	2005	ALL	Chassis	VSES	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2005	ALL	Body	Amplifier (Bose)	V	V																			V																																					
C	2005	ALL	Body	Body Control Module	V	V																		V	V																																				
C	2005	ALL	Body	CD Changer	V																																																							
C	2005	ALL	Body	Chime	V	V																		V	V																																				
C	2005	ALL	Body	Disc Player and Video Display	V																				V																																				
C	2005	ALL	Body	Driver Door Module	V	V																		V	V																																				
C	2005	ALL	Body	Driver Seat Module	V	V																		V	V																																				
C	2005	ALL	Body	Generator Battery Control Module	V	V																		V	V																																				
C	2005	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																				
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																				
C	2005	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																				
C	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																				
C	2005	ALL	Body	Passenger Door Module	V	V																		V	V																																				
C	2005	ALL	Body	Passenger Presence System																																																								
C	2005	ALL	Body	Base Radio	V	V																			V																																				
C	2005	ALL	Body	Uplevel Radio	V	V																			V																																				
C	2005	ALL	Body	Navigation Radio	V	V																		V																																				
C	2005	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																				
C	2005	ALL	Body	Rear HVAC	V	V																			V																																				
C	2005	ALL	Body	Rear Seat Audio	V	V																			V																																				
C	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
C	2005	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
C	2005	ALL	Body	Vehicle Theft Deterrent	V	V																																																						
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM	V	V										V	V				V	V		V	V							V														V														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM		V																		V																																				
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM		V																		V																																				
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM		V																		V																																				
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM	V	V																		V										V	V																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V	V		V	V							V														V														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V										V	V																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V	V		V	V							V														V														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V										V	V																								
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V														
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V														V														
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V										V	V																								
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module	V	V										V	V				V	V		V	V							V														V														
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module	V	V																		V										V	V																								
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V														V														
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V	V		V	V							V														V														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																								
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module	V	V										V					V			V								V														V														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module	V	V										V	V				V			V	V							V														V														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600	V	V																		V										V	V																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600	V	V																		V										V	V																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V			V	V							V														V														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V										V	V																								
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module	V	V															V			V																																				
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module	V	V																		V										V	V	V																								
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display		V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V															V			V																																						
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V										V	V	V																								
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display		V																		V	V																																			
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module	V	V										V	V				V	V		V	V							V														V														
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed	V	V																		V										V	V	V																								
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed	V	V																		V										V	V																								
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW	V	V																		V	V																																			
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW	V	V																		V																																				
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																			
C	2006	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																			
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)		V																		V																																				
C	2006	ALL	Chassis	ESC	V	V																		V	V																																			
C	2006	ALL	Chassis	Tire Pressure Monitor	V	V																																																					
C	2006	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
C	2006	ALL	Chassis	VSES	V	V																		V	V																																		
C	2006	ALL	Body	Amplifier (Bose)	V	V																			V																																		
C	2006	ALL	Body	Body Control Module	V	V																		V	V																																		
C	2006	ALL	Body	CD Changer	V																																																					
C	2006	ALL	Body	Chime	V	V																		V	V																																		
C	2006	ALL	Body	Disc Player and Video Display	V																				V																																		
C	2006	ALL	Body	Driver Door Module	V	V																		V	V																																		
C	2006	ALL	Body	Driver Seat Module	V	V																		V	V																																		
C	2006	ALL	Body	Generator Battery Control Module	V	V																		V	V																																		
C	2006	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																		
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																		
C	2006	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																		
C	2006	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2006	ALL	Body	Passenger Door Module	V	V																		V	V																																		
C	2006	ALL	Body	Passenger Presence System																																																						
C	2006	ALL	Body	Base Radio	V	V																			V																																		
C	2006	ALL	Body	Uplevel Radio	V	V																			V																																		
C	2006	ALL	Body	Navigation Radio	V	V																		V																																		
C	2006	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																		
C	2006	ALL	Body	Rear HVAC	V	V																			V																																		
C	2006	ALL	Body	Rear Seat Audio	V	V																			V																																		
C	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
C	2006	ALL	Body	Vehicle Theft Deterrent	V	V																																																				
C	2006	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V														
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V														
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																		
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V																									
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V														
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																		
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																									
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V														
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																								
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V														
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																		
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																		
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V													
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module	V	V																		V	V																																		
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V										V	V	V																							
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V						V			V	V																																		
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																		
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																		
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																							
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V																								
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																								
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
C	2007	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2007	Sierra	Chassis	Trailer Brake Control Module	V	V																			V																																		
C	2007	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2007	Sierra	Body	Body Control Module	V	V																		V	V																																		
C	2007	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2007	Sierra	Body	Digital Radio Receiver	V	V																			V																																		
C	2007	Sierra	Body	Driver Door Switch	V	V																		V	V																																		
C	2007	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2007	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2007	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2007	Sierra	Body	Memory Seat Module	V	V																		V	V																																		
C	2007	Sierra	Body	Park Assist Module	V	V																		V	V																																		
C	2007	Sierra	Body	Passenger Door Switch	V	V																		V	V																																		
C	2007	Sierra	Body	Passenger Presence System	V	V																			V																																		
C	2007	Sierra	Body	Radio	V	V																		V	V																																		
C	2007	Sierra	Body	Rear Heated Seat Module	V	V																			V																																		
C	2007	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2007	Sierra	Body	Rollover Sensor	V	V																			V																																		
C	2007	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2007	Sierra	Body	Theft Deterrent Module	V	V																			V																																		
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																								
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																								
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V													
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V										V	V	V																							
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
C	2007	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2007	Yukon	Chassis	Trailer Brake Control Module	V	V																			V																																		
C	2007	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2007	Yukon	Body	Assist Step Controller	V	V																		V	V																																			
C	2007	Yukon	Body	Body Control Module	V	V																		V	V																																		
C	2007	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2007	Yukon	Body	Digital Radio Receiver	V	V																			V																																		
C	2007	Yukon	Body	Driver Door Switch	V	V																		V	V																																		
C	2007	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2007	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2007	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2007	Yukon	Body	Lift Gate Module	V	V																		V	V																																		
C	2007	Yukon	Body	Memory Seat Module	V	V																		V	V																																		
C	2007	Yukon	Body	Park Assist Module	V	V																		V	V																																		
C	2007	Yukon	Body	Passenger Door Switch	V	V																		V	V																																		
C	2007	Yukon	Body	Passenger Presence System	V	V																			V																																		
C	2007	Yukon	Body	Radio	V	V																		V	V																																		
C	2007	Yukon	Body	Rear Heated Seat Module	V	V																			V																																		
C	2007	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2007	Yukon	Body	Rollover Sensor	V	V																			V																																		
C	2007	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2007	Yukon	Body	Theft Deterrent Module	V	V																			V																																		
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V													
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V											V	V																						
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V													
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V											V	V																						
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V											V	V																						
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V													
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V											V	V	V																						
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V																						
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V																						
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
C	2007	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2007	Yukon XL	Chassis	Trailer Brake Control Module	V	V																			V																																		
C	2007	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2007	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																		
C	2007	Yukon XL	Body	Body Control Module	V	V																		V	V																																		
C	2007	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2007	Yukon XL	Body	Digital Radio Receiver	V	V																			V																																		
C	2007	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																		
C	2007	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2007	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2007	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2007	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																		
C	2007	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																		
C	2007	Yukon XL	Body	Park Assist Module	V	V																		V	V																																		
C	2007	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																		
C	2007	Yukon XL	Body	Passenger Presence System	V	V																			V																																		
C	2007	Yukon XL	Body	Radio	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2007	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																			
C	2007	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2007	Yukon XL	Body	Rollover Sensor	V	V																			V																																		
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2007	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																		
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V														V													
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																		
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V																								
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V													
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V													
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																								
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V						V														V													
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																							
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V													
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																		
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																								
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V						V														V													
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																		
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V						V														V													
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module	V	V																		V	V																																		
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V										V	V	V																							
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V						V			V	V																																		
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																		
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																		
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																							
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V													
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V																								
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V													
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																								
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
C	2008	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2008	Sierra	Chassis	Trailer Brake Control Module	V	V																			V																																		
C	2008	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2008	Sierra	Body	Body Control Module	V	V																		V	V																																		
C	2008	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2008	Sierra	Body	Digital Radio Receiver	V	V																			V																																		
C	2008	Sierra	Body	Driver Door Switch	V	V																		V	V																																		
C	2008	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2008	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2008	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2008	Sierra	Body	Memory Seat Module	V	V																		V	V																																		
C	2008	Sierra	Body	Park Assist Module	V	V																		V	V																																		
C	2008	Sierra	Body	Passenger Door Switch	V	V																		V	V																																		
C	2008	Sierra	Body	Passenger Presence System	V	V																			V																																		
C	2008	Sierra	Body	Radio	V	V																		V	V																																		
C	2008	Sierra	Body	Rear Heated Seat Module	V	V																			V																																		
C	2008	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2008	Sierra	Body	Rollover Sensor	V	V																			V																																				
C	2008	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																				
C	2008	Sierra	Body	Theft Deterrent Module	V	V																			V																																				
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																									
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																									
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V														
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V										V	V	V																								
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																									
C	2008	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2008	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2008	Yukon	Chassis	Trailer Brake Control Module	V	V																			V																																			
C	2008	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2008	Yukon	Body	Assist Step Controller	V	V																		V	V																																			
C	2008	Yukon	Body	Body Control Module	V	V																		V	V																																			
C	2008	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2008	Yukon	Body	Digital Radio Receiver	V	V																			V																																			
C	2008	Yukon	Body	Driver Door Switch	V	V																		V	V																																			
C	2008	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2008	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2008	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2008	Yukon	Body	Lift Gate Module	V	V																		V	V																																			
C	2008	Yukon	Body	Memory Seat Module	V	V																		V	V																																			
C	2008	Yukon	Body	Park Assist Module	V	V																		V	V																																			
C	2008	Yukon	Body	Passenger Door Switch	V	V																		V	V																																			
C	2008	Yukon	Body	Passenger Presence System	V	V																			V																																			
C	2008	Yukon	Body	Radio	V	V																		V	V																																			
C	2008	Yukon	Body	Rear Heated Seat Module	V	V																			V																																			
C	2008	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2008	Yukon	Body	Rollover Sensor	V	V																			V																																			
C	2008	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2008	Yukon	Body	Theft Deterrent Module	V	V																			V																																			
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1		V																																																				
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2		V																																																				
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module	V	V																																																					
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module	V	V																			V																																			
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Right Front Solenoid Valves	ABS Left Front Solenoid Valves	ABS Right Rear Solenoid Valves	ABS Left Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2008	Yukon Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	Body Control Module	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	Digital Radio Receiver	V	V																			V																																			
C	2008	Yukon Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	Lift Gate Module	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	Memory Seat Module	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	Park Assist Module	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	Passenger Presence System	V	V																			V																																			
C	2008	Yukon Hybrid	Body	Radio	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	Rollover Sensor	V	V																			V																																			
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2008	Yukon Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V													
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V																									
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																							
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																									
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V										V	V	V																							
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V																									
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																									
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW	V	V																			V																																			
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
C	2008	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2008	Yukon XL	Chassis	Trailer Brake Control Module	V	V																			V																																			
C	2008	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2008	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																			
C	2008	Yukon XL	Body	Body Control Module	V	V																		V	V																																			
C	2008	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2008	Yukon XL	Body	Digital Radio Receiver	V	V																			V																																			
C	2008	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																			
C	2008	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2008	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2008	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2008	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																			
C	2008	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2008	Yukon XL	Body	Park Assist Module	V	V																		V	V																																				
C	2008	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																				
C	2008	Yukon XL	Body	Passenger Presence System	V	V																			V																																				
C	2008	Yukon XL	Body	Radio	V	V																		V	V																																				
C	2008	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																				
C	2008	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																				
C	2008	Yukon XL	Body	Rollover Sensor	V	V																			V																																				
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																				
C	2008	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																				
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V														V														
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V														V														
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V	V	V		V				V			V	V	V	V		V	V		V	V						V														V														
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																							
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																			
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																			
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES	V	V																		V	V																																			
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES	V	V																		V	V																																			
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																			
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																			
C	2009	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2009	Sierra	Chassis	Trailer Brake Control Module	V	V																			V																																			
C	2009	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2009	Sierra	Body	Body Control Module	V	V																		V	V																																			
C	2009	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2009	Sierra	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2009	Sierra	Body	Driver Door Switch	V	V																		V	V																																			
C	2009	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2009	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2009	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2009	Sierra	Body	Memory Seat Module	V	V																		V	V																																			
C	2009	Sierra	Body	Park Assist Module	V	V																		V	V																																			
C	2009	Sierra	Body	Passenger Door Switch	V	V																		V	V																																			
C	2009	Sierra	Body	Passenger Presence System	V	V																			V																																			
C	2009	Sierra	Body	Radio	V	V																		V	V																																			
C	2009	Sierra	Body	Rear Heated Seat Module	V	V																			V																																			
C	2009	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2009	Sierra	Body	Rollover Sensor	V	V																			V																																			
C	2009	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2009	Sierra	Body	Theft Deterrent Module	V	V																			V																																			
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V													
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1		V																																																					
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2		V																																																				
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module	V	V																																																					
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module	V	V																			V																																			
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
C	2009	Sierra Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	Body Control Module	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	Memory Seat Module	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	Park Assist Module	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	Passenger Presence System	V	V																			V																																			
C	2009	Sierra Hybrid	Body	Radio	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	Rollover Sensor	V	V																			V																																			
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2009	Sierra Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed	V	V																		V										V	V																							
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																			
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																		
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed	V	V																		V										V	V																							
C	2009	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2009	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2009	Yukon	Chassis	Trailer Brake Control Module	V	V																			V																																		
C	2009	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2009	Yukon	Body	Assist Step Controller	V	V																		V	V																																		
C	2009	Yukon	Body	Body Control Module	V	V																		V	V																																		
C	2009	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2009	Yukon	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2009	Yukon	Body	Driver Door Switch	V	V																		V	V																																		
C	2009	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2009	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2009	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2009	Yukon	Body	Left Side Object Detection Module	V	V																		V	V																																		
C	2009	Yukon	Body	Lift Gate Module	V	V																		V	V																																		
C	2009	Yukon	Body	Memory Seat Module	V	V																		V	V																																		
C	2009	Yukon	Body	Park Assist Module	V	V																		V	V																																		
C	2009	Yukon	Body	Passenger Door Switch	V	V																		V	V																																		
C	2009	Yukon	Body	Passenger Presence System	V	V																			V																																		
C	2009	Yukon	Body	Radio	V	V																		V	V																																		
C	2009	Yukon	Body	Rear Heated Seat Module	V	V																			V																																		
C	2009	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2009	Yukon	Body	Right Side Object Detection Module	V	V																			V																																		
C	2009	Yukon	Body	Rollover Sensor	V	V																			V																																		
C	2009	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2009	Yukon	Body	Theft Deterrent Module	V	V																			V																																		
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																		
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																		
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																		
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																		
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1		V																																																				
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2		V																																																				
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module	V	V																																																				
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module	V	V																			V																																		
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		
C	2009	Yukon Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2009	Yukon Hybrid	Body	Body Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																					
C	2009	Yukon Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																				
C	2009	Yukon Hybrid	Body	Driver Door Switch	V	V																		V	V																																				
C	2009	Yukon Hybrid	Body	Heated Seat Module	V	V																			V																																				
C	2009	Yukon Hybrid	Body	HVAC Control Module	V	V																		V	V																																				
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																				
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																				
C	2009	Yukon Hybrid	Body	Park Assist Module	V	V																		V	V																																				
C	2009	Yukon Hybrid	Body	Passenger Door Switch	V	V																		V	V																																				
C	2009	Yukon Hybrid	Body	Passenger Presence System	V	V																			V																																				
C	2009	Yukon Hybrid	Body	Radio	V	V																		V	V																																				
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module	V	V																			V																																				
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																				
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module	V	V																			V																																				
C	2009	Yukon Hybrid	Body	Rollover Sensor	V	V																			V																																				
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																				
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																				
C	2009	Yukon Hybrid	Body	Theft Deterrent Module	V	V																			V																																				
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V															
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																				
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V															
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V															
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																				
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V															
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																				
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V															
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																				
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V															
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																				
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																				
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																				
C	2009	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																				
C	2009	Yukon XL	Chassis	Trailer Brake Control Module	V	V																			V																																				
C	2009	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																				
C	2009	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																				
C	2009	Yukon XL	Body	Body Control Module	V	V																		V	V																																				
C	2009	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																				
C	2009	Yukon XL	Body	Digital Radio Receiver	V	V																		V	V																																				
C	2009	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																				
C	2009	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																				
C	2009	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																				
C	2009	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																				
C	2009	Yukon XL	Body	Left Side Object Detection Module	V	V																		V	V																																				
C	2009	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																				
C	2009	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2009	Yukon XL	Body	Park Assist Module	V	V																		V	V																																					
C	2009	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																					
C	2009	Yukon XL	Body	Passenger Presence System	V	V																			V																																					
C	2009	Yukon XL	Body	Radio	V	V																		V	V																																					
C	2009	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																					
C	2009	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																					
C	2009	Yukon XL	Body	Right Side Object Detection Module	V	V																			V																																					
C	2009	Yukon XL	Body	Rollover Sensor	V	V																			V																																					
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																					
C	2009	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																					
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V															
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																									
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V														V															
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V														V															
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V											V	V	V																								
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V															
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																								
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V														V															
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																					
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V																									
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																					
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																					
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																					
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V											V	V	V																								
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V															
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																					
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V	V																								
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V														V															
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																					
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																								
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V															
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																					
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																								
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES	V	V																		V	V																																					
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES	V	V																		V	V																																					
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																					
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																					
C	2010	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																					
C	2010	Sierra	Chassis	Trailer Brake Control Module	V	V																		V	V																																					
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																					
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																					
C	2010	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																					
C	2010	Sierra	Body	Body Control Module	V	V																		V	V																																					
C	2010	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																					
C	2010	Sierra	Body	Digital Radio Receiver	V	V																		V	V																																					
C	2010	Sierra	Body	Driver Door Switch	V	V																		V	V																																					
C	2010	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																					
C	2010	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																					
C	2010	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																					
C	2010	Sierra	Body	Memory Seat Module	V	V																		V	V																																					
C	2010	Sierra	Body	Park Assist Module	V	V																			V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2010	Sierra	Body	Passenger Door Switch	V	V																		V	V																																					
C	2010	Sierra	Body	Passenger Presence System	V	V																			V																																					
C	2010	Sierra	Body	Radio	V	V																		V	V																																					
C	2010	Sierra	Body	Rear Heated Seat Module	V	V																			V																																					
C	2010	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																					
C	2010	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																					
C	2010	Sierra	Body	Theft Deterrent Module	V	V																			V																																					
C	2010	Sierra Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V															
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module	V	V																		V																																					
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module		V																		V																																					
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																					
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																					
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1		V																																																							
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2		V																																																							
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module	V	V																		V											V		V																									
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																					
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																					
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																					
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module	V	V																																																							
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module	V	V																			V																																					
C	2010	Sierra Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																					
C	2010	Sierra Hybrid	Body	Body Control Module	V	V																		V	V																																					
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																					
C	2010	Sierra Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																					
C	2010	Sierra Hybrid	Body	Driver Door Switch	V	V																		V	V																																					
C	2010	Sierra Hybrid	Body	Heated Seat Module	V	V																			V																																					
C	2010	Sierra Hybrid	Body	HVAC Control Module	V	V																		V	V																																					
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																					
C	2010	Sierra Hybrid	Body	Park Assist Module	V	V																			V																																					
C	2010	Sierra Hybrid	Body	Passenger Door Switch	V	V																		V	V																																					
C	2010	Sierra Hybrid	Body	Passenger Presence System	V	V																			V																																					
C	2010	Sierra Hybrid	Body	Radio	V	V																		V	V																																					
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module	V	V																			V																																					
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																					
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																					
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																					
C	2010	Sierra Hybrid	Body	Theft Deterrent Module	V	V																			V																																					
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V															
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																					
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V											V	V	V																									
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V															
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																					
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																									
C	2010	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V																																					
C	2010	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																					
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																					
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																					
C	2010	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																					
C	2010	Yukon	Body	Assist Step Controller	V	V																		V	V																																					
C	2010	Yukon	Body	Body Control Module	V	V																		V	V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2010	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2010	Yukon	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2010	Yukon	Body	Driver Door Switch	V	V																		V	V																																			
C	2010	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																			
C	2010	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																			
C	2010	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2010	Yukon	Body	Left Side Object Detection Module	V	V																		V	V																																			
C	2010	Yukon	Body	Lift Gate Module	V	V																		V	V																																			
C	2010	Yukon	Body	Memory Seat Module	V	V																		V	V																																			
C	2010	Yukon	Body	Park Assist Module	V	V																			V																																			
C	2010	Yukon	Body	Passenger Door Switch	V	V																		V	V																																			
C	2010	Yukon	Body	Passenger Presence System	V	V																			V																																			
C	2010	Yukon	Body	Radio	V	V																		V	V																																			
C	2010	Yukon	Body	Rear Heated Seat Module	V	V																			V																																			
C	2010	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2010	Yukon	Body	Right Side Object Detection Module	V	V																			V																																			
C	2010	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																			
C	2010	Yukon	Body	Theft Deterrent Module	V	V																			V																																			
C	2010	Yukon Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V														
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module	V	V																		V																																			
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module		V																		V																																			
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																			
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1		V																																																					
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2		V																																																					
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module	V	V																		V											V		V																							
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module	V	V																																																					
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
C	2010	Yukon Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Body Control Module	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Heated Seat Module	V	V																			V																																			
C	2010	Yukon Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Lift Gate Module	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Park Assist Module	V	V																			V																																			
C	2010	Yukon Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Passenger Presence System	V	V																			V																																			
C	2010	Yukon Hybrid	Body	Radio	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module	V	V																			V																																			
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
C	2010	Yukon Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																		
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																							
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V														
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																		
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW	V	V																		V	V																																		
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW	V	V																		V	V																																		
C	2010	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																		
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
C	2010	Yukon XL	Chassis	Trailer Brake Control Module	V	V																		V	V																																		
C	2010	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																		
C	2010	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																		
C	2010	Yukon XL	Body	Body Control Module	V	V																		V	V																																		
C	2010	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																		
C	2010	Yukon XL	Body	Digital Radio Receiver	V	V																		V	V																																		
C	2010	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																		
C	2010	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																		
C	2010	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																		
C	2010	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																		
C	2010	Yukon XL	Body	Left Side Object Detection Module	V	V																		V	V																																		
C	2010	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																		
C	2010	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																		
C	2010	Yukon XL	Body	Park Assist Module	V	V																			V																																		
C	2010	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																		
C	2010	Yukon XL	Body	Passenger Presence System	V	V																			V																																		
C	2010	Yukon XL	Body	Radio	V	V																		V	V																																		
C	2010	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																		
C	2010	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																		
C	2010	Yukon XL	Body	Right Side Object Detection Module	V	V																			V																																		
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
C	2010	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																		
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																			V														
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module	V	V																		V	V									V	V	V																							
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System	V	V																			V																																		
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module	V	V																		V										V	V																								
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module	V	V																		V	V									V	V	V																							
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System	V	V																			V																																		
D	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
D	2008	ALL	Body	Body Control Module	V	V																		V	V																																		
D	2008	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
D	2008	ALL	Body	Headlamp Control Module	V	V																			V																																			
D	2008	ALL	Body	HVAC Control Module Auto	V																			V	V																																			
D	2008	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
D	2008	ALL	Body	Park Assist Module	V	V																			V																																			
D	2008	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
D	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
D	2008	ALL	Body	Theft Deterrent Module	V	V																			V																																			
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module	V	V																		V	V									V	V	V																							
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System	V	V																			V																																			
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module	V	V																		V										V	V																									
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module	V	V																		V	V									V	V	V																							
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System	V	V																			V																																			
D	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
D	2009	ALL	Body	Body Control Module	V	V																		V	V																																			
D	2009	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																			
D	2009	ALL	Body	Headlamp Control Module	V	V																			V																																			
D	2009	ALL	Body	HVAC Control Module Auto	V																			V	V																																			
D	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
D	2009	ALL	Body	Park Assist Module	V	V																			V																																			
D	2009	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
D	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
D	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																			
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module	V	V																		V	V									V	V	V																							
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System	V	V																			V																																			
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module	V	V																		V										V	V	V																							
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System	V	V																			V																																			
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module	V	V																		V										V	V																									
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module	V	V																		V	V									V	V	V																							
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System	V	V																			V																																			
D	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
D	2010	ALL	Body	Body Control Module	V	V																		V	V																																			
D	2010	ALL	Body	Body Control Module (aux.)	V	V																		V	V																																			
D	2010	ALL	Body	Headlamp Control Module	V	V																			V																																			
D	2010	ALL	Body	HVAC Control Module Auto	V																			V	V																																			
D	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
D	2010	ALL	Body	Park Assist Module	V	V																			V																																			
D	2010	ALL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
D	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V			V	V							V														V														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V										V	V																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V			V	V							V														V														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V	V									V	V																									
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V														
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V			V	V							V														V														
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V										V	V																									
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V			V	V							V														V														
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2004	Express/Savana	Chassis	Anti-lock Brake System	V	V																		V	V																																			
G	2004	Express/Savana	Chassis	VSES	V	V																		V	V																																			
G	2004	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
G	2004	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2004	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																			
G	2004	Express/Savana	Body	OnStar	V	V																		V	V																																			
G	2004	Express/Savana	Body	Base Radio	V	V																			V																																			
G	2004	Express/Savana	Body	Uplevel Radio	V	V																			V																																			
G	2004	Express/Savana	Body	Remote Function Actuation	V	V																																																					
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V			V	V							V													V														
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V											V	V																							
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V			V	V							V													V														
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V											V	V																							
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V														
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V											V	V																							
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V			V	V							V													V														
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V											V	V																							
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System	V	V																		V	V																																			
G	2004	Express Access/Savana Pro	Chassis	VSES	V	V																		V	V																																			
G	2004	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																			
G	2004	Express Access/Savana Pro	Body	OnStar	V	V																		V	V																																			
G	2004	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																			
G	2004	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																			
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation	V	V																																																					
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																					
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V														
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module	V	V																		V											V	V																							
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V										V	V																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V													
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V										V	V																								
G	2005	Express/Savana	Chassis	Anti-lock Brake System	V	V																		V	V																																		
G	2005	Express/Savana	Chassis	VSES	V	V																		V	V																																		
G	2005	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
G	2005	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
G	2005	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																		
G	2005	Express/Savana	Body	Base Radio	V	V																			V																																		
G	2005	Express/Savana	Body	Uplevel Radio	V	V																			V																																		
G	2005	Express/Savana	Body	Remote Function Actuation	V	V																																																				
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																				
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V													
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V													
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control	V	V																		V										V	V																							
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V													
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control	V	V																		V										V	V																							
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module	V	V										V	V				V	V		V	V							V													V													
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module	V	V																		V										V	V																							
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V													
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																							
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V													
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																							
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V													
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V										V	V																							
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V													
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V										V	V																							
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System	V	V																		V	V																																		
G	2005	Express Access/Savana Pro	Chassis	VSES	V	V																		V	V																																		
G	2005	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																		
G	2005	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																		
G	2005	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																		
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation	V	V																																																				
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																				
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V													
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V													
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control	V	V																		V										V	V																							
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V													
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control	V	V																		V										V	V																							
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V													
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																							
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V													
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																							
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V													
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V										V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V																		V																																			
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V											V	V																							
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display		V																		V	V																																		
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display		V																		V	V																																		
G	2006	Express/Savana	Chassis	Anti-lock Brake System	V	V																		V	V																																		
G	2006	Express/Savana	Chassis	VSES	V	V																		V	V																																		
G	2006	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
G	2006	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
G	2006	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																		
G	2006	Express/Savana	Body	Passenger Presence System																																																							
G	2006	Express/Savana	Body	Base Radio	V	V																			V																																		
G	2006	Express/Savana	Body	Uplevel Radio	V	V																			V																																		
G	2006	Express/Savana	Body	Remote Function Actuation	V	V																																																				
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																				
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V																		V																																			
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V											V	V																							
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display		V																		V	V																																		
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display		V																		V	V																																		
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System	V	V																		V	V																																		
G	2006	Express Access/Savana Pro	Chassis	VSES	V	V																		V	V																																		
G	2006	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																		
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																						
G	2006	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																		
G	2006	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																		
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation	V	V																																																				
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																				
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V														
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V															V			V																																				
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display		V																		V	V																																			
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display		V																		V	V																																			
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V																									
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display		V																		V	V																																			
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display		V																		V	V																																			
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2007	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
G	2007	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2007	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																			
G	2007	Express/Savana	Body	Passenger Presence System																																																							
G	2007	Express/Savana	Body	Base Radio	V	V																			V																																			
G	2007	Express/Savana	Body	Uplevel Radio	V	V																			V																																			
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																																																					
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																					
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V															V			V																																				
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display		V																		V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display		V																		V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display		V																		V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display		V																		V	V																																			
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2007	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																			
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2007	Express Access/Savana Pro	Body	Radio	V	V																			V																																			
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																			V																																			
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																																																					
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																					
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																									
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																									
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																									
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V							V							V			V	V																																			
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V																									
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2008	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
G	2008	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2008	Express/Savana	Body	Passenger Presence System	V	V																			V																																			
G	2008	Express/Savana	Body	Radio	V	V																		V	V																																			
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
G	2008	Express/Savana	Body	Rollover Sensor	V	V																			V																																			
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2008	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																			
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																									
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																									
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V							V							V			V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V																									
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																				
G	2008	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2008	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																			
G	2008	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																			
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
G	2008	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																			
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																			
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V															
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V															
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V															
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V													V															
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																								
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																			
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V																								
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2009	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
G	2009	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2009	Express/Savana	Body	Passenger Presence System	V	V																			V																																			
G	2009	Express/Savana	Body	Radio	V	V																		V	V																																			
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
G	2009	Express/Savana	Body	Rollover Sensor	V	V																			V																																			
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2009	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																			
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V															
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V															
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V													V															
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V													V															
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module		V																		V	V																																			
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																			
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V																								
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																			
G	2009	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
G	2009	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																			
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																			
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																							
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V																		V	V																																		
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																		
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																		
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																		
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																							
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module		V																		V	V																																		
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																		
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																		
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																							
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
G	2010	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
G	2010	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
G	2010	Express/Savana	Body	Passenger Presence System	V	V																			V																																		
G	2010	Express/Savana	Body	Radio	V	V																		V	V																																		
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
G	2010	Express/Savana	Body	Rollover Sensor	V	V																			V																																		
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																		
G	2010	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																		
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																							
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																		
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																		
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																		
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																							
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module		V																		V	V																																		
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																		
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																		
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																							
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
G	2010	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
G	2010	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																			
G	2010	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																			
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
G	2010	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																			
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																			
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																			
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V			V	V							V													V														
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V											V	V																							
H	2004	Express/Savana	Chassis	Anti-lock Brake System	V	V																		V	V																																			
H	2004	Express/Savana	Chassis	VSES	V	V																		V	V																																			
H	2004	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
H	2004	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2004	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																			
H	2004	Express/Savana	Body	OnStar	V	V																		V	V																																			
H	2004	Express/Savana	Body	Base Radio	V	V																			V																																			
H	2004	Express/Savana	Body	Uplevel Radio	V	V																			V																																			
H	2004	Express/Savana	Body	Remote Function Actuation	V	V																																																					
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																					
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V			V	V							V													V														
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V											V	V																							
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System	V	V																		V	V																																			
H	2004	Express Access/Savana Pro	Chassis	VSES	V	V																		V	V																																			
H	2004	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																			
H	2004	Express Access/Savana Pro	Body	OnStar	V	V																		V	V																																			
H	2004	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																			
H	2004	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																			
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation	V	V																																																					
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																					
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V											V	V																							
H	2005	Express/Savana	Chassis	Anti-lock Brake System	V	V																		V	V																																			
H	2005	Express/Savana	Chassis	VSES	V	V																		V	V																																			
H	2005	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
H	2005	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2005	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																			
H	2005	Express/Savana	Body	Base Radio	V	V																			V																																			
H	2005	Express/Savana	Body	Uplevel Radio	V	V																			V																																			
H	2005	Express/Savana	Body	Remote Function Actuation	V	V																																																					
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																					
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V														
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V											V	V																							
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V														
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V											V	V																							
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System	V	V																		V	V																																			
H	2005	Express Access/Savana Pro	Chassis	VSES	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2005	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																			
H	2005	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																			
H	2005	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																			
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation	V	V																																																					
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																					
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V						V													V														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																							
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V						V													V														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																							
H	2006	Express/Savana	Chassis	Anti-lock Brake System	V	V																		V	V																																			
H	2006	Express/Savana	Chassis	VSES	V	V																		V	V																																			
H	2006	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
H	2006	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2006	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																			
H	2006	Express/Savana	Body	Passenger Presence System																																																								
H	2006	Express/Savana	Body	Base Radio	V	V																			V																																			
H	2006	Express/Savana	Body	Uplevel Radio	V	V																			V																																			
H	2006	Express/Savana	Body	Remote Function Actuation	V	V																																																					
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																					
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V						V													V														
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																							
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V						V													V														
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																							
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System	V	V																		V	V																																			
H	2006	Express Access/Savana Pro	Chassis	VSES	V	V																		V	V																																			
H	2006	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																			
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																							
H	2006	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																			
H	2006	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																			
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation	V	V																																																					
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																					
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V						V													V														
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																							
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V						V													V														
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																							
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V						V													V														
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																							
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
H	2007	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
H	2007	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2007	Express/Savana	Body	Multifunction Alarm Module	V	V																		V	V																																			
H	2007	Express/Savana	Body	Passenger Presence System																																																							
H	2007	Express/Savana	Body	Base Radio	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2007	Express/Savana	Body	Uplevel Radio	V	V																			V																																			
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																																																					
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																																																					
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V													V													
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																							
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control	V	V										V	V				V			V	V							V													V													
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control	V	V																		V										V	V																							
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control	V	V										V	V				V	V		V	V							V													V													
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control	V	V																		V										V	V																							
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2007	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module	V	V																		V	V																																		
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																							
H	2007	Express Access/Savana Pro	Body	Base Radio	V	V																			V																																		
H	2007	Express Access/Savana Pro	Body	Uplevel Radio	V	V																			V																																		
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																																																				
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																																																				
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V													
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																							
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V													
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V													
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																							
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
H	2008	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
H	2008	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
H	2008	Express/Savana	Body	Passenger Presence System	V	V																			V																																		
H	2008	Express/Savana	Body	Radio	V	V																		V	V																																		
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
H	2008	Express/Savana	Body	Rollover Sensor	V	V																			V																																		
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																		
H	2008	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																		
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V													
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																							
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V													
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V													
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																							
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2008	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2008	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																			
H	2008	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																			
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
H	2008	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																			
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																			
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																			
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V													
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V													
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V													
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V														V													
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																								
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
H	2009	Express/Savana	Body	Body Control Module	V	V																		V	V																																			
H	2009	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2009	Express/Savana	Body	Passenger Presence System	V	V																			V																																			
H	2009	Express/Savana	Body	Radio	V	V																		V	V																																			
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
H	2009	Express/Savana	Body	Rollover Sensor	V	V																			V																																			
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																			
H	2009	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																			
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V													
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V													
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																								
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V													
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																			
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V						V														V													
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V																								
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																			
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																			
H	2009	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																			
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																			
H	2009	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																			
H	2009	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																			
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
H	2009	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																			
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																			
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																			
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																							
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V																		V	V																																			
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																	
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																	
H	2010	Express/Savana	Body	Body Control Module	V	V																		V	V																																	
H	2010	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																	
H	2010	Express/Savana	Body	Passenger Presence System		V																			V																																	
H	2010	Express/Savana	Body	Radio	V	V																		V	V																																	
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
H	2010	Express/Savana	Body	Rollover Sensor	V	V																			V																																	
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																	
H	2010	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																	
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																					
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																	
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																					
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																	
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																	
H	2010	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																	
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																	
H	2010	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																	
H	2010	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																	
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
H	2010	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																	
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																	
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																	
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM	V	V										V	V				V	V		V	V							V													V													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM		V																		V																																	
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM		V																		V																																	
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM		V																		V																																	
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM	V	V																		V										V	V																							
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case	V	V																		V																																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V	V		V	V							V													V													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V										V	V																							
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V	V		V	V							V													V													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V										V	V																							
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case	V	V																		V																																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case	V	V																		V																																	
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V													
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case	V	V																		V																																	
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V													V													
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V										V	V																							
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case	V	V																		V																																	
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V													V													
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																							
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable	V	V																		V																																	
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control	V	V																		V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V	V		V	V							V													V															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable	V	V																		V																																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable	V	V																		V																																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control	V	V																		V																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module	V	V										V	V				V			V	V							V													V															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600	V	V																		V										V	V																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600	V	V																		V										V	V																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable	V	V																		V																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable	V	V																		V																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control	V	V																		V																																				
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V			V	V							V													V															
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V										V	V																									
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module	V	V																		V	V																																			
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module	V	V																		V										V	V	V																								
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case	V	V																		V																																				
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V																		V																																				
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V										V	V	V																								
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case	V	V																		V																																				
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module	V	V										V	V				V	V		V	V							V													V															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed	V	V																		V										V	V																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed	V	V																		V										V	V	V																								
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable	V	V																		V																																				
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable	V	V																		V																																				
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW	V	V																		V																																				
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																			
K	2004	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																			
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)		V																		V																																				
K	2004	ALL	Chassis	ESC	V	V																		V	V																																			
K	2004	ALL	Chassis	Rear Wheel Steering	V	V																		V	V																																			
K	2004	ALL	Chassis	Tire Pressure Monitor	V	V																																																					
K	2004	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
K	2004	ALL	Chassis	VSES	V	V																		V	V																																			
K	2004	ALL	Body	Amplifier (Bose)	V	V																			V																																			
K	2004	ALL	Body	Body Control Module	V	V																		V	V																																			
K	2004	ALL	Body	CD Changer	V																																																						
K	2004	ALL	Body	Chime	V	V																		V	V																																			
K	2004	ALL	Body	Driver Door Module	V	V																		V	V																																			
K	2004	ALL	Body	Driver Seat Module	V	V																		V	V																																			
K	2004	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
K	2004	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																			
K	2004	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2004	ALL	Body	OnStar	V	V																		V	V																																			
K	2004	ALL	Body	Passenger Door Module	V	V																		V	V																																			
K	2004	ALL	Body	Passenger Presence System																																																							
K	2004	ALL	Body	Radio Base	V	V																			V																																			
K	2004	ALL	Body	Radio Uplevel	V	V																			V																																			
K	2004	ALL	Body	Radio Navigation	V	V																		V																																				
K	2004	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
K	2004	ALL	Body	Rear HVAC	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2004	ALL	Body	Rear Seat Audio	V	V																			V																																		
K	2004	ALL	Body	Rear Seat Entertainment	V																				V																																		
K	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
K	2004	ALL	Body	Vehicle Theft Deterrent	V	V																																																					
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM		V																		V																																			
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM		V																		V																																			
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM		V																		V																																			
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC	V	V																		V																																			
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC	V	V																		V																																			
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC	V	V																		V																																			
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case	V	V																		V																																			
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case	V	V																		V																																			
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case	V	V																		V																																			
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable	V	V																		V																																			
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control	V	V																		V																																			
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable	V	V																		V																																			
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable	V	V																		V																																			
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control	V	V																		V																																			
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module	V	V										V	V				V			V	V							V														V													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable	V	V																		V																																			
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable	V	V																		V																																			
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control	V	V																		V																																			
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V			V	V							V														V													
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V																		V																																			
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V										V	V	V																							
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case	V	V																		V																																			
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed	V	V																		V										V	V																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed	V	V																		V										V	V	V																							
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable	V	V																		V																																			
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable	V	V																		V																																			
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW	V	V																		V																																					
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																				
K	2005	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																				
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)		V																		V																																					
K	2005	ALL	Chassis	ESC	V	V																		V	V																																				
K	2005	ALL	Chassis	Rear Wheel Steering	V	V																		V	V																																				
K	2005	ALL	Chassis	Tire Pressure Monitor	V	V																																																							
K	2005	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																					
K	2005	ALL	Chassis	VSES	V	V																		V	V																																				
K	2005	ALL	Body	Amplifier (Bose)	V	V																			V																																				
K	2005	ALL	Body	Body Control Module	V	V																		V	V																																				
K	2005	ALL	Body	CD Changer	V																																																							
K	2005	ALL	Body	Chime	V	V																		V	V																																				
K	2005	ALL	Body	Disc Player and Video Display	V																				V																																				
K	2005	ALL	Body	Driver Door Module	V	V																		V	V																																				
K	2005	ALL	Body	Driver Seat Module	V	V																		V	V																																				
K	2005	ALL	Body	Generator Battery Control Module	V	V																		V	V																																				
K	2005	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																				
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																				
K	2005	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																				
K	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																				
K	2005	ALL	Body	Passenger Door Module	V	V																		V	V																																				
K	2005	ALL	Body	Passenger Presence System																																																								
K	2005	ALL	Body	Base Radio	V	V																			V																																				
K	2005	ALL	Body	Uplevel Radio	V	V																			V																																				
K	2005	ALL	Body	Navigation Radio	V	V																		V																																				
K	2005	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																				
K	2005	ALL	Body	Rear HVAC	V	V																			V																																				
K	2005	ALL	Body	Rear Seat Audio	V	V																			V																																				
K	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
K	2005	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
K	2005	ALL	Body	Vehicle Theft Deterrent	V	V																																																						
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM	V	V										V	V				V	V		V	V							V														V														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM		V																		V																																					
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM		V																		V																																					
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM		V																		V																																					
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM	V	V																		V										V	V																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC	V	V																		V																																					
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM	V	V										V	V				V	V		V	V							V														V														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM	V	V																		V										V	V																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM	V	V										V	V				V	V		V	V							V														V														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM	V	V																		V										V	V																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC	V	V																		V																																					
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V														
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case	V	V																		V																																					
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module	V	V										V	V				V	V		V	V							V														V														
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module	V	V																		V										V	V																									
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case	V	V																		V																																					
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module	V	V										V	V				V	V		V	V							V														V														
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module	V	V																		V										V	V																									

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case	V	V																		V																																				
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module	V	V																		V										V	V																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable	V	V																		V																																				
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control	V	V																		V																																				
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module	V	V																		V										V	V																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable	V	V																		V																																				
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable	V	V																		V																																				
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control	V	V																		V																																				
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module	V	V										V	V				V			V	V							V													V														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600	V	V																		V										V	V																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600	V	V																		V										V	V																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable	V	V																		V																																				
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable	V	V																		V																																				
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control	V	V																		V																																				
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module	V	V										V	V				V			V	V							V													V														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module	V	V																		V										V	V																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable	V	V																		V																																				
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable	V	V																		V																																				
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module	V	V															V			V																																				
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module	V	V																		V										V	V	V																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display		V																		V	V																																			
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case	V	V																		V																																				
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module	V	V															V			V																																				
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module	V	V																		V										V	V	V																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display		V																		V	V																																			
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case	V	V																		V																																				
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed	V	V																		V										V	V	V																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed	V	V																		V										V	V																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable	V	V																		V																																				
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable	V	V																		V																																				
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW	V	V																		V	V																																			
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW	V	V																		V																																				
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT	V	V																		V	V																																			
K	2006	ALL	Chassis	ABS Over 8600 GVW	V	V																		V	V																																			
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)		V																		V																																				
K	2006	ALL	Chassis	ESC	V	V																		V	V																																			
K	2006	ALL	Chassis	Tire Pressure Monitor	V	V																																																					
K	2006	ALL	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
K	2006	ALL	Chassis	VSES	V	V																		V	V																																			
K	2006	ALL	Body	Amplifier (Bose)	V	V																			V																																			
K	2006	ALL	Body	Body Control Module	V	V																		V	V																																			
K	2006	ALL	Body	CD Changer	V																																																					
K	2006	ALL	Body	Chime	V	V																		V	V																																			
K	2006	ALL	Body	Disc Player and Video Display	V																				V																																			
K	2006	ALL	Body	Driver Door Module	V	V																		V	V																																			
K	2006	ALL	Body	Driver Seat Module	V	V																		V	V																																			
K	2006	ALL	Body	Generator Battery Control Module	V	V																		V	V																																			
K	2006	ALL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT	V	V																		V	V																																			
K	2006	ALL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
K	2006	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2006	ALL	Body	Passenger Door Module	V	V																		V	V																																			
K	2006	ALL	Body	Passenger Presence System																																																							
K	2006	ALL	Body	Base Radio	V	V																			V																																			
K	2006	ALL	Body	Uplevel Radio	V	V																			V																																			
K	2006	ALL	Body	Navigation Radio	V	V																		V																																			
K	2006	ALL	Body	Rear Aux. Climate Module	V	V																		V	V																																			
K	2006	ALL	Body	Rear HVAC	V	V																			V																																			
K	2006	ALL	Body	Rear Seat Audio	V	V																			V																																			
K	2006	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
K	2006	ALL	Body	Vehicle Theft Deterrent	V	V																																																						
K	2006	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V											V	V																							
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V											V	V																							
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V											V	V	V																						
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V											V	V																							
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V											V	V																							
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V											V	V	V																							
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V							V							V			V	V																																			
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V											V	V	V																							
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V																							
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																					V													
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V																							
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
K	2007	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2007	Sierra	Chassis	Trailer Brake Control Module	V	V																			V																																		
K	2007	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2007	Sierra	Body	Body Control Module	V	V																		V	V																																		
K	2007	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2007	Sierra	Body	Digital Radio Receiver	V	V																			V																																		
K	2007	Sierra	Body	Driver Door Switch	V	V																		V	V																																		
K	2007	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2007	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2007	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2007	Sierra	Body	Memory Seat Module	V	V																		V	V																																		
K	2007	Sierra	Body	Park Assist Module	V	V																		V	V																																		
K	2007	Sierra	Body	Passenger Door Switch	V	V																		V	V																																		
K	2007	Sierra	Body	Passenger Presence System	V	V																			V																																		
K	2007	Sierra	Body	Radio	V	V																		V	V																																		
K	2007	Sierra	Body	Rear Heated Seat Module	V	V																			V																																		
K	2007	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2007	Sierra	Body	Rollover Sensor	V	V																			V																																		
K	2007	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2007	Sierra	Body	Theft Deterrent Module	V	V																			V																																		
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																							
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																							
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module	V	V																		V	V																																		
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V														
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V										V	V	V																							
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																							
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																		
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																		
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																		
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
K	2007	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2007	Yukon	Chassis	Trailer Brake Control Module	V	V																			V																																		
K	2007	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2007	Yukon	Body	Assist Step Controller	V	V																		V	V																																		
K	2007	Yukon	Body	Body Control Module	V	V																		V	V																																		
K	2007	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2007	Yukon	Body	Digital Radio Receiver	V	V																			V																																		
K	2007	Yukon	Body	Driver Door Switch	V	V																		V	V																																		
K	2007	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2007	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2007	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2007	Yukon	Body	Lift Gate Module	V	V																		V	V																																		
K	2007	Yukon	Body	Memory Seat Module	V	V																		V	V																																		
K	2007	Yukon	Body	Park Assist Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2007	Yukon	Body	Passenger Door Switch	V	V																		V	V																																			
K	2007	Yukon	Body	Passenger Presence System	V	V																			V																																			
K	2007	Yukon	Body	Radio	V	V																		V	V																																			
K	2007	Yukon	Body	Rear Heated Seat Module	V	V																			V																																			
K	2007	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2007	Yukon	Body	Rollover Sensor	V	V																			V																																			
K	2007	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2007	Yukon	Body	Theft Deterrent Module	V	V																			V																																			
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V														
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V											V	V																							
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V														
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V											V	V																							
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V											V	V																							
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V													V														
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V											V	V	V																							
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V																							
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																			
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V			V	V		V	V																				V														
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V																							
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
K	2007	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2007	Yukon XL	Chassis	Trailer Brake Control Module	V	V																			V																																			
K	2007	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2007	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																			
K	2007	Yukon XL	Body	Body Control Module	V	V																		V	V																																			
K	2007	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2007	Yukon XL	Body	Digital Radio Receiver	V	V																			V																																			
K	2007	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																			
K	2007	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2007	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2007	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2007	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																			
K	2007	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																			
K	2007	Yukon XL	Body	Park Assist Module	V	V																		V	V																																			
K	2007	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																			
K	2007	Yukon XL	Body	Passenger Presence System	V	V																			V																																			
K	2007	Yukon XL	Body	Radio	V	V																		V	V																																			
K	2007	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																			
K	2007	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2007	Yukon XL	Body	Rollover Sensor	V	V																			V																																			
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2007	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																			
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																				
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V																									
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																									
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																								
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																									
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																									
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V										V	V	V																								
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V							V							V			V	V																																			
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																			
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																								
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V																									
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																									
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES	V	V																		V	V																																			
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES	V	V																		V	V																																			
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
K	2008	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2008	Sierra	Chassis	Trailer Brake Control Module	V	V																			V																																			
K	2008	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2008	Sierra	Body	Body Control Module	V	V																		V	V																																			
K	2008	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2008	Sierra	Body	Digital Radio Receiver	V	V																			V																																			
K	2008	Sierra	Body	Driver Door Switch	V	V																		V	V																																			
K	2008	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2008	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2008	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2008	Sierra	Body	Memory Seat Module	V	V																		V	V																																			
K	2008	Sierra	Body	Park Assist Module	V	V																		V	V																																			
K	2008	Sierra	Body	Passenger Door Switch	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2008	Sierra	Body	Passenger Presence System	V	V																			V																																			
K	2008	Sierra	Body	Radio	V	V																		V	V																																		
K	2008	Sierra	Body	Rear Heated Seat Module	V	V																			V																																			
K	2008	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2008	Sierra	Body	Rollover Sensor	V	V																			V																																			
K	2008	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2008	Sierra	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
K	2008	Sierra	Body	Theft Deterrent Module	V	V																			V																																			
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																									
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																			
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																									
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V										V	V	V																								
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																									
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
K	2008	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2008	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2008	Yukon	Chassis	Trailer Brake Control Module	V	V																			V																																			
K	2008	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2008	Yukon	Body	Assist Step Controller	V	V																		V	V																																			
K	2008	Yukon	Body	Body Control Module	V	V																		V	V																																			
K	2008	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2008	Yukon	Body	Digital Radio Receiver	V	V																			V																																			
K	2008	Yukon	Body	Driver Door Switch	V	V																		V	V																																			
K	2008	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2008	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2008	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2008	Yukon	Body	Lift Gate Module	V	V																		V	V																																			
K	2008	Yukon	Body	Memory Seat Module	V	V																		V	V																																			
K	2008	Yukon	Body	Park Assist Module	V	V																		V	V																																			
K	2008	Yukon	Body	Passenger Door Switch	V	V																		V	V																																			
K	2008	Yukon	Body	Passenger Presence System	V	V																			V																																			
K	2008	Yukon	Body	Radio	V	V																		V	V																																			
K	2008	Yukon	Body	Rear Heated Seat Module	V	V																			V																																			
K	2008	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2008	Yukon	Body	Rollover Sensor	V	V																			V																																			
K	2008	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2008	Yukon	Body	Theft Deterrent Module	V	V																			V																																			
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V													
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1		V																																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2		V																																																						
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																		
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module	V	V																																																					
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module	V	V																			V																																		
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		
K	2008	Yukon Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	Body Control Module	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	Digital Radio Receiver	V	V																			V																																		
K	2008	Yukon Hybrid	Body	Driver Door Switch	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	HVAC Control Module	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	Lift Gate Module	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	Memory Seat Module	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	Park Assist Module	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	Passenger Door Switch	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	Passenger Presence System	V	V																			V																																		
K	2008	Yukon Hybrid	Body	Radio	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module	V	V																			V																																		
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	Rollover Sensor	V	V																			V																																		
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																		
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2008	Yukon Hybrid	Body	Theft Deterrent Module	V	V																			V																																		
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V													
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																		
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V																								
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																		
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																							
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																		
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																		
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V																								
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																		
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V													
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module	V	V																		V	V																																		
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module	V	V																		V										V	V	V																							
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V																								
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																		
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V																								
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																		
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW	V	V																			V																																		
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2008	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2008	Yukon XL	Chassis	Trailer Brake Control Module	V	V																			V																																		
K	2008	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2008	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																		
K	2008	Yukon XL	Body	Body Control Module	V	V																		V	V																																		
K	2008	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2008	Yukon XL	Body	Digital Radio Receiver	V	V																			V																																		
K	2008	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																		
K	2008	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2008	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2008	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2008	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																		
K	2008	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																		
K	2008	Yukon XL	Body	Park Assist Module	V	V																		V	V																																		
K	2008	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																		
K	2008	Yukon XL	Body	Passenger Presence System	V	V																			V																																		
K	2008	Yukon XL	Body	Radio	V	V																		V	V																																		
K	2008	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																		
K	2008	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2008	Yukon XL	Body	Rollover Sensor	V	V																			V																																		
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2008	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																		
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V												
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V	V																						
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V												
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V												
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V	V																						
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V												
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V												
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																						
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V												
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed	V	V																		V										V	V	V																						
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed	V	V																		V										V	V																						
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V												
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																							
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V								V				V		V			V	V																																		
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																		
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																						
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																						
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed	V	V																		V										V	V	V																						
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed	V	V																		V										V	V																						
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES	V	V																		V	V																																		
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES	V	V																		V	V																																		
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																		
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																		
K	2009	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2009	Sierra	Chassis	Trailer Brake Control Module	V	V																			V																																		
K	2009	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2009	Sierra	Body	Body Control Module	V	V																		V	V																																		
K	2009	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2009	Sierra	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2009	Sierra	Body	Driver Door Switch	V	V																		V	V																																		
K	2009	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2009	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2009	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2009	Sierra	Body	Memory Seat Module	V	V																		V	V																																		
K	2009	Sierra	Body	Park Assist Module	V	V																		V	V																																		
K	2009	Sierra	Body	Passenger Door Switch	V	V																		V	V																																		
K	2009	Sierra	Body	Passenger Presence System	V	V																			V																																		
K	2009	Sierra	Body	Radio	V	V																		V	V																																		
K	2009	Sierra	Body	Rear Heated Seat Module	V	V																			V																																		
K	2009	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2009	Sierra	Body	Rollover Sensor	V	V																			V																																		
K	2009	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2009	Sierra	Body	Theft Deterrent Module	V	V																			V																																		
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																		
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																		
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																		
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1		V																																																				
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2		V																																																				
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																						
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																		
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module	V	V																																																				
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module	V	V																			V																																		
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2009	Sierra Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																					
K	2009	Sierra Hybrid	Body	Body Control Module	V	V																		V	V																																				
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																				
K	2009	Sierra Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																				
K	2009	Sierra Hybrid	Body	Driver Door Switch	V	V																		V	V																																				
K	2009	Sierra Hybrid	Body	HVAC Control Module	V	V																		V	V																																				
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																				
K	2009	Sierra Hybrid	Body	Memory Seat Module	V	V																		V	V																																				
K	2009	Sierra Hybrid	Body	Park Assist Module	V	V																		V	V																																				
K	2009	Sierra Hybrid	Body	Passenger Door Switch	V	V																		V	V																																				
K	2009	Sierra Hybrid	Body	Passenger Presence System	V	V																			V																																				
K	2009	Sierra Hybrid	Body	Radio	V	V																		V	V																																				
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module	V	V																			V																																				
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																				
K	2009	Sierra Hybrid	Body	Rollover Sensor	V	V																			V																																				
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																				
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																				
K	2009	Sierra Hybrid	Body	Theft Deterrent Module	V	V																			V																																				
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V						V														V															
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																	V	V																																				
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed	V	V																		V										V	V	V																							
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed	V	V																		V										V	V																							
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																			
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V						V														V															
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module	V	V																	V	V																																				
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module	V	V																		V										V	V																							
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module	V	V																		V	V																																			
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V						V														V															
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																	V	V																																				
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																			
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V						V														V															
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																	V	V																																				
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																			
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V						V														V															
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed	V	V																	V	V										V	V	V																							
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed	V	V																	V	V										V	V																							
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																	V	V																																				
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																	V	V																																				
K	2009	Yukon	Chassis	Electronic Brake Control Module	V	V																	V	V																																				
K	2009	Yukon	Chassis	Electronic Suspension Control	V	V																	V	V																																				
K	2009	Yukon	Chassis	Trailer Brake Control Module	V	V																		V																																				
K	2009	Yukon	Body	Amplifier (Bose)	V	V																	V	V																																				
K	2009	Yukon	Body	Assist Step Controller	V	V																	V	V																																				
K	2009	Yukon	Body	Body Control Module	V	V																	V	V																																				
K	2009	Yukon	Body	Body Control Module (aux.)	V	V																	V	V																																				
K	2009	Yukon	Body	Digital Radio Receiver	V	V																	V	V																																				
K	2009	Yukon	Body	Driver Door Switch	V	V																	V	V																																				
K	2009	Yukon	Body	HVAC Control Module Auto	V	V																	V	V																																				
K	2009	Yukon	Body	HVAC Control Module Manual	V	V																	V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2009	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2009	Yukon	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2009	Yukon	Body	Lift Gate Module	V	V																		V	V																																			
K	2009	Yukon	Body	Memory Seat Module	V	V																		V	V																																			
K	2009	Yukon	Body	Park Assist Module	V	V																		V	V																																			
K	2009	Yukon	Body	Passenger Door Switch	V	V																		V	V																																			
K	2009	Yukon	Body	Passenger Presence System	V	V																			V																																			
K	2009	Yukon	Body	Radio	V	V																		V	V																																			
K	2009	Yukon	Body	Rear Heated Seat Module	V	V																			V																																			
K	2009	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2009	Yukon	Body	Right Side Object Detection Module	V	V																			V																																			
K	2009	Yukon	Body	Rollover Sensor	V	V																			V																																			
K	2009	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2009	Yukon	Body	Theft Deterrent Module	V	V																			V																																			
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V													
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module	V	V																		V																																			
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module		V																		V																																			
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module	V	V																		V	V																																			
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																		V																																			
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1		V																																																					
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2		V																																																				
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module	V	V																		V										V		V																							
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module	V	V																		V	V																																			
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module	V	V																																																					
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module	V	V																			V																																			
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
K	2009	Yukon Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Body Control Module	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Heated Seat Module	V	V																			V																																			
K	2009	Yukon Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Park Assist Module	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Passenger Presence System	V	V																			V																																			
K	2009	Yukon Hybrid	Body	Radio	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module	V	V																			V																																			
K	2009	Yukon Hybrid	Body	Rollover Sensor	V	V																			V																																			
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2009	Yukon Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V													
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module	V	V																		V	V																																			
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module	V	V																		V										V	V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module	V	V																		V	V																																				
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																		
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																		
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																		
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																		
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
K	2009	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																		
K	2009	Yukon XL	Chassis	Trailer Brake Control Module	V	V																			V																																		
K	2009	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																		
K	2009	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																		
K	2009	Yukon XL	Body	Body Control Module	V	V																		V	V																																		
K	2009	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																		
K	2009	Yukon XL	Body	Digital Radio Receiver	V	V																		V	V																																		
K	2009	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																		
K	2009	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																		
K	2009	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																		
K	2009	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																		
K	2009	Yukon XL	Body	Left Side Object Detection Module	V	V																		V	V																																		
K	2009	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																		
K	2009	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																		
K	2009	Yukon XL	Body	Park Assist Module	V	V																		V	V																																		
K	2009	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																		
K	2009	Yukon XL	Body	Passenger Presence System	V	V																			V																																		
K	2009	Yukon XL	Body	Radio	V	V																		V	V																																		
K	2009	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																		
K	2009	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																		
K	2009	Yukon XL	Body	Right Side Object Detection Module	V	V																			V																																		
K	2009	Yukon XL	Body	Rollover Sensor	V	V																			V																																		
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
K	2009	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																		
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																		
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V													V														
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V													V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module	V	V																		V										V	V	V																								
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module	V	V																		V	V																																		
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																	
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																							
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module	V	V																		V	V																																	
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V	V	V							V				V		V				V	V																																	
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module		V																		V	V																																	
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module	V	V																		V	V																																	
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module	V	V																		V										V	V	V																						
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module	V	V																		V	V																																	
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																	
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																						
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																	
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																	
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																						
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																	
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																	
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																						
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																	
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES	V	V																		V	V																																	
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES	V	V																		V	V																																	
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																	
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																	
K	2010	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																	
K	2010	Sierra	Chassis	Trailer Brake Control Module	V	V																		V	V																																	
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																	
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																	
K	2010	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																	
K	2010	Sierra	Body	Body Control Module	V	V																		V	V																																	
K	2010	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																	
K	2010	Sierra	Body	Digital Radio Receiver	V	V																		V	V																																	
K	2010	Sierra	Body	Driver Door Switch	V	V																		V	V																																	
K	2010	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																	
K	2010	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																	
K	2010	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																	
K	2010	Sierra	Body	Memory Seat Module	V	V																		V	V																																	
K	2010	Sierra	Body	Park Assist Module	V	V																			V																																	
K	2010	Sierra	Body	Passenger Door Switch	V	V																		V	V																																	
K	2010	Sierra	Body	Passenger Presence System	V	V																			V																																	
K	2010	Sierra	Body	Radio	V	V																		V	V																																	
K	2010	Sierra	Body	Rear Heated Seat Module	V	V																			V																																	
K	2010	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																	
K	2010	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																	
K	2010	Sierra	Body	Theft Deterrent Module	V	V																			V																																	
K	2010	Sierra Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V												
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module	V	V																		V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module		V																		V																																					
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																				
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1		V																																																						
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2		V																																																						
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module	V	V																		V											V		V																							
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module	V	V																																																						
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
K	2010	Sierra Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2010	Sierra Hybrid	Body	Body Control Module	V	V																		V	V																																			
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2010	Sierra Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2010	Sierra Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
K	2010	Sierra Hybrid	Body	Heated Seat Module	V	V																			V																																			
K	2010	Sierra Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2010	Sierra Hybrid	Body	Park Assist Module	V	V																			V																																			
K	2010	Sierra Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
K	2010	Sierra Hybrid	Body	Passenger Presence System	V	V																			V																																			
K	2010	Sierra Hybrid	Body	Radio	V	V																		V	V																																			
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2010	Sierra Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V											V	V	V																							
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module	V	V																		V	V																																			
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																							
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																			
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																			
K	2010	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2010	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2010	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2010	Yukon	Body	Assist Step Controller	V	V																		V	V																																			
K	2010	Yukon	Body	Body Control Module	V	V																		V	V																																			
K	2010	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2010	Yukon	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2010	Yukon	Body	Driver Door Switch	V	V																		V	V																																			
K	2010	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2010	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2010	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2010	Yukon	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2010	Yukon	Body	Lift Gate Module	V	V																		V	V																																			
K	2010	Yukon	Body	Memory Seat Module	V	V																		V	V																																			
K	2010	Yukon	Body	Park Assist Module	V	V																			V																																			
K	2010	Yukon	Body	Passenger Door Switch	V	V																		V	V																																			
K	2010	Yukon	Body	Passenger Presence System	V	V																			V																																			
K	2010	Yukon	Body	Radio	V	V																		V	V																																			
K	2010	Yukon	Body	Rear Heated Seat Module	V	V																			V																																			
K	2010	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2010	Yukon	Body	Right Side Object Detection Module	V	V																			V																																			
K	2010	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2010	Yukon	Body	Theft Deterrent Module	V	V																			V																																			
K	2010	Yukon Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V													
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module	V	V																		V																																			
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module		V																		V																																			
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																			
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1		V																																																					
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2		V																																																					
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module	V	V																		V										V		V																							
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module	V	V																																																					
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
K	2010	Yukon Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Body Control Module	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Heated Seat Module	V	V																			V																																			
K	2010	Yukon Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Lift Gate Module	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Park Assist Module	V	V																			V																																			
K	2010	Yukon Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Passenger Presence System	V	V																			V																																			
K	2010	Yukon Hybrid	Body	Radio	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module	V	V																			V																																			
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2010	Yukon Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V															
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																				
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																								
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module	V	V																		V	V																																			
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed	V	V																		V	V																																			
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed	V	V																		V	V																																			
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V														
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed	V	V																		V	V																																			
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed	V	V																		V	V																																			
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed	V	V																		V	V																																			
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed	V	V																		V	V																																			
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW	V	V																		V	V																																			
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW	V	V																		V	V																																			
K	2010	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
K	2010	Yukon XL	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
K	2010	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																			
K	2010	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																			
K	2010	Yukon XL	Body	Body Control Module	V	V																		V	V																																			
K	2010	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																			
K	2010	Yukon XL	Body	Digital Radio Receiver	V	V																		V	V																																			
K	2010	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																			
K	2010	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																			
K	2010	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																			
K	2010	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																			
K	2010	Yukon XL	Body	Left Side Object Detection Module	V	V																		V	V																																			
K	2010	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																			
K	2010	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																			
K	2010	Yukon XL	Body	Park Assist Module	V	V																			V																																			
K	2010	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																			
K	2010	Yukon XL	Body	Passenger Presence System	V	V																			V																																			
K	2010	Yukon XL	Body	Radio	V	V																		V	V																																			
K	2010	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																			
K	2010	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																			
K	2010	Yukon XL	Body	Right Side Object Detection Module	V	V																			V																																			
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
K	2010	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																			
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V													V															
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display	V	V																		V																																				
L	2004	ALL	Chassis	4WAL 3 Sensor	V	V																		V																																				
L	2004	ALL	Body	Body Control Module	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2004	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
L	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																								
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display	V	V																		V																																				
L	2005	ALL	Chassis	4WAL 3 Sensor	V	V																		V																																				
L	2005	ALL	Body	Body Control Module	V	V																		V																																				
L	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
L	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																												
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V														
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
L	2010	Terrain	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																										
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																		
L	2010	Terrain	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
L	2010	Terrain	Body	Body Control Module	V	V																		V	V																																		
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
L	2010	Terrain	Body	Passenger Presence Module	V	V																			V																																		
L	2010	Terrain	Body	Instrument Cluster	V	V																		V	V																																		
L	2010	Terrain	Body	Radio	V	V																		V	V																																		
L	2010	Terrain	Body	Multimedia Player Interface Module	V	V																			V																																		
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8	V	V																		V	V																																		
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
L	2010	Terrain	Body	Liftgate Control Module	V	V																			V																					V													
L	2010	Terrain	Body	Parking Assist Control Module	V																				V																																		
L	2010	Terrain	Body	Frontview Camera Module	V	V																		V	V																																		
L	2010	Terrain	Body	Vehicle Direction Camera Control Module	V	V																		V	V																																		
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																												
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V														
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V									V													
L	2011	Terrain	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																										
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																		
L	2011	Terrain	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
L	2011	Terrain	Body	Body Control Module	V	V																		V	V																																		
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
L	2011	Terrain	Body	Passenger Presence Module	V	V																			V																																		
L	2011	Terrain	Body	Instrument Cluster	V	V																		V	V																																		
L	2011	Terrain	Body	Radio	V	V																		V	V																																		
L	2011	Terrain	Body	Multimedia Player Interface Module	V	V																			V																																		
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
L	2011	Terrain	Body	Liftgate Control Module	V	V																			V																						V												
L	2011	Terrain	Body	Parking Assist Control Module	V																				V																																		
L	2011	Terrain	Body	Frontview Camera Module	V	V																		V	V																																		
L	2011	Terrain	Body	Vehicle Direction Camera Control Module	V	V																		V	V																																		
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																										
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module	V	V																		V	V									V	V	V	V									V												
L	2012	Terrain	Powertrain	Fuel Pump Control Module	V	V																		V	V							V		V																									
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																		
L	2012	Terrain	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
L	2012	Terrain	Body	Body Control Module	V	V																		V	V																																		
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
L	2012	Terrain	Body	Passenger Presence Module	V	V																			V																																		
L	2012	Terrain	Body	Instrument Cluster	V	V																		V	V																																		
L	2012	Terrain	Body	Radio	V	V																		V	V																																		
L	2012	Terrain	Body	Multimedia Player Interface Module	V	V																			V																																		
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
L	2012	Terrain	Body	Liftgate Control Module	V	V																			V																						V												
L	2012	Terrain	Body	Parking Assist Control Module	V																			V	V																																		
L	2012	Terrain	Body	Frontview Camera Module	V	V																		V	V																																		
L	2012	Terrain	Body	Vehicle Direction Camera Control Module	V	V																		V	V																																		
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																										
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																			
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V		V													
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V												
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																		
L	2013	Terrain	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																V	V
L	2013	Terrain	Chassis	Power Steering Control Module	V	V																			V																																		
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																		
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																		
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
L	2013	Terrain	Body	Passenger Presence Module	V	V																			V																																		
L	2013	Terrain	Body	Instrument Cluster	V	V																		V	V																																		
L	2013	Terrain	Body	Radio	V	V																		V	V																																		
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
L	2013	Terrain	Body	Liftgate Control Module	V	V																			V																						V												
L	2013	Terrain	Body	Right Side Object Detection Control Module	V																			V	V																																		
L	2013	Terrain	Body	Left Side Object Detection Control Module	V																			V	V																																		
L	2013	Terrain	Body	Parking Assist Control Module	V																			V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2013	Terrain	Body	Frontview Camera Module	V	V																		V	V																																				
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V																											
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V															
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V								V															
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																			
L	2014	Terrain	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
L	2014	Terrain	Chassis	Power Steering Control Module	V	V																			V																																			
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																			
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																			
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
L	2014	Terrain	Body	Passenger Presence Module	V	V																			V																																			
L	2014	Terrain	Body	Instrument Cluster	V	V																		V	V																																			
L	2014	Terrain	Body	Radio	V	V																		V	V																																			
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
L	2014	Terrain	Body	Liftgate Control Module	V	V																			V																						V													
L	2014	Terrain	Body	Right Side Object Detection Control Module	V																			V	V																																			
L	2014	Terrain	Body	Left Side Object Detection Control Module	V																			V	V																																			
L	2014	Terrain	Body	Parking Assist Control Module	V																			V	V																																			
L	2014	Terrain	Body	Frontview Camera Module	V	V																		V	V																																			
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V																											
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V															
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V								V															
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																			
L	2015	Terrain	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
L	2015	Terrain	Chassis	Power Steering Control Module	V	V																			V																																			
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																			
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																			
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
L	2015	Terrain	Body	Passenger Presence Module	V	V																			V																																			
L	2015	Terrain	Body	Instrument Cluster	V	V																		V	V																																			
L	2015	Terrain	Body	Radio	V	V																		V	V																																			
L	2015	Terrain	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
L	2015	Terrain	Body	Liftgate Control Module	V	V																			V																						V													
L	2015	Terrain	Body	Seat Memory Control Module	V																																																						
L	2015	Terrain	Body	Right Side Object Detection Control Module	V																			V	V																																			
L	2015	Terrain	Body	Left Side Object Detection Control Module	V																			V	V																																			
L	2015	Terrain	Body	Parking Assist Control Module	V																			V	V																																			
L	2015	Terrain	Body	Frontview Camera Module	V	V																		V	V																																			
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V																											
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module	V	V																		V	V									V	V	V	V	V	V																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V															
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V														
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module	V	V																			V																																			
L	2016	Terrain	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	V	V
L	2016	Terrain	Chassis	Power Steering Control Module	V	V																			V																																		
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																		
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																		
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
L	2016	Terrain	Body	Passenger Presence Module	V	V																			V																																		
L	2016	Terrain	Body	Instrument Cluster	V	V																		V	V																																		
L	2016	Terrain	Body	Radio	V	V																		V	V																																		
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
L	2016	Terrain	Body	Liftgate Control Module	V	V																		V	V																							V											
L	2016	Terrain	Body	Seat Memory Control Module	V																																																					
L	2016	Terrain	Body	Right Side Object Detection Control Module	V																			V	V																																		
L	2016	Terrain	Body	Left Side Object Detection Control Module	V																			V	V																																		
L	2016	Terrain	Body	Parking Assist Control Module	V																			V	V																																		
L	2016	Terrain	Body	Frontview Camera Module	V	V																		V	V																																		
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
M	2004	ALL	Chassis	4WAL 3 Sensor	V	V																		V																																			
M	2004	ALL	Body	Body Control Module	V	V																		V																																			
M	2004	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
M	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
M	2005	ALL	Chassis	4WAL 3 Sensor	V	V																		V																																			
M	2005	ALL	Body	Body Control Module	V	V																		V																																			
M	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
M	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module	V	V										V					V			V							V														V													
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module	V	V										V					V			V							V														V													
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module	V	V										V					V			V							V														V													
P	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
P	2007	ALL	Body	Theft Deterrent Module	V	V																																																				
R	2007	ALL	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V															V	V	V	V		V													
R	2007	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V	V																							
R	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
R	2007	ALL	Body	Body Control Module	V	V																		V	V																																		
R	2007	ALL	Body	Digital Radio Receiver	V	V																			V																																		
R	2007	ALL	Body	Driver Door Switch	V	V																		V	V																																		
R	2007	ALL	Body	Head Up Display	V	V																			V																																		
R	2007	ALL	Body	Heated Seat Module	V	V																			V																																		
R	2007	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																		
R	2007	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																		
R	2007	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2007	ALL	Body	Lift Gate Module	V	V																		V	V																																			
R	2007	ALL	Body	Park Assist Module	V	V																		V	V																																		
R	2007	ALL	Body	Passenger Door Switch	V	V																		V	V																																		
R	2007	ALL	Body	Passenger Presence System	V	V																			V																																		
R	2007	ALL	Body	Radio	V	V																		V	V																																		
R	2007	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																		
R	2007	ALL	Body	Rollover Sensor	V	V																			V																																		
R	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
R	2007	ALL	Body	Theft Deterrent Module	V	V																			V																																		
R	2008	ALL	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V															V	V	V	V		V													
R	2008	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V	V																						
R	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
R	2008	ALL	Body	Body Control Module	V	V																		V	V																																		
R	2008	ALL	Body	Digital Radio Receiver	V	V																			V																																		
R	2008	ALL	Body	Driver Door Switch	V	V																		V	V																																		
R	2008	ALL	Body	Head Up Display	V	V																			V																																		
R	2008	ALL	Body	Heated Seat Module	V	V																			V																																		
R	2008	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																		
R	2008	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																		
R	2008	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
R	2008	ALL	Body	Lift Gate Module	V	V																		V	V																																		
R	2008	ALL	Body	Park Assist Module	V	V																		V	V																																		
R	2008	ALL	Body	Passenger Door Switch	V	V																		V	V																																		
R	2008	ALL	Body	Passenger Presence System	V	V																			V																																		
R	2008	ALL	Body	Radio	V	V																		V	V																																		
R	2008	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																		
R	2008	ALL	Body	Rollover Sensor	V	V																			V																																		
R	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
R	2008	ALL	Body	Theft Deterrent Module	V	V																			V																																		
R	2009	ALL	Powertrain	Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V															V	V	V	V															
R	2009	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																		
R	2009	ALL	Powertrain	Transmission Control Module	V	V																		V										V	V	V																						
R	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
R	2009	ALL	Body	Body Control Module	V	V																		V	V																																		
R	2009	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
R	2009	ALL	Body	Driver Door Switch	V	V																		V	V																																		
R	2009	ALL	Body	Head Up Display	V	V																			V																																		
R	2009	ALL	Body	Heated Seat Module	V	V																			V																																		
R	2009	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																		
R	2009	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																		
R	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
R	2009	ALL	Body	Lift Gate Module	V	V																		V	V																																		
R	2009	ALL	Body	Park Assist Module	V	V																		V	V																																		
R	2009	ALL	Body	Passenger Door Switch	V	V																		V	V																																		
R	2009	ALL	Body	Passenger Presence System	V	V																			V																																		
R	2009	ALL	Body	Radio	V	V																		V	V																																		
R	2009	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																		
R	2009	ALL	Body	Rollover Sensor	V	V																			V																																		
R	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
R	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																		
R	2010	ALL	Powertrain	Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V								V								V	V	V	V															

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2010	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
R	2010	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
R	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
R	2010	ALL	Body	Body Control Module	V	V																		V	V																																			
R	2010	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
R	2010	ALL	Body	Driver Door Switch	V	V																		V	V																																			
R	2010	ALL	Body	Head Up Display	V	V																			V																																			
R	2010	ALL	Body	Heated Seat Module	V	V																			V																																			
R	2010	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
R	2010	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
R	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
R	2010	ALL	Body	Lift Gate Module	V	V																		V	V																																			
R	2010	ALL	Body	Park Assist Module	V	V																			V																																			
R	2010	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
R	2010	ALL	Body	Passenger Presence System	V	V																			V																																			
R	2010	ALL	Body	Radio	V	V																		V	V																																			
R	2010	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
R	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
R	2010	ALL	Body	Theft Deterrent Module	V	V																			V																																			
R	2011	ALL	Powertrain	Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V							V								V	V	V	V																
R	2011	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
R	2011	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
R	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
R	2011	ALL	Body	Body Control Module	V	V																		V	V																																			
R	2011	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
R	2011	ALL	Body	Driver Door Switch	V	V																		V	V																																			
R	2011	ALL	Body	Head Up Display	V	V																			V																																			
R	2011	ALL	Body	Heated Seat Module	V	V																			V																																			
R	2011	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
R	2011	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
R	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
R	2011	ALL	Body	Lift Gate Module	V	V																		V	V																																			
R	2011	ALL	Body	Park Assist Module	V	V																			V																																			
R	2011	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
R	2011	ALL	Body	Passenger Presence System	V	V																			V																																			
R	2011	ALL	Body	Radio	V	V																		V	V																																			
R	2011	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
R	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
R	2011	ALL	Body	Theft Deterrent Module	V	V																			V																																			
R	2012	ALL	Powertrain	Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V														
R	2012	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
R	2012	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
R	2012	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		V	
R	2012	ALL	Body	Body Control Module	V	V																		V	V																																			
R	2012	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
R	2012	ALL	Body	Driver Door Switch	V	V																		V	V																																			
R	2012	ALL	Body	Head Up Display	V	V																			V																																			
R	2012	ALL	Body	Heated Seat Module	V	V																			V																																			
R	2012	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
R	2012	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
R	2012	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2012	ALL	Body	Lift Gate Module	V	V																		V	V																																		
R	2012	ALL	Body	Park Assist Module	V	V																			V																																	
R	2012	ALL	Body	Passenger Door Switch	V	V																		V	V																																	
R	2012	ALL	Body	Passenger Presence System	V	V																			V																																	
R	2012	ALL	Body	Radio	V	V																		V	V																																	
R	2012	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																	
R	2012	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																	
R	2012	ALL	Body	Theft Deterrent Module	V	V																			V																																	
R	2013	ALL	Powertrain	Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V													
R	2013	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																	
R	2013	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																					
R	2013	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																	V	
R	2013	ALL	Body	Body Control Module	V	V																		V	V																																	
R	2013	ALL	Body	Digital Radio Receiver	V	V																		V	V																																	
R	2013	ALL	Body	Driver Door Switch	V	V																		V	V																																	
R	2013	ALL	Body	Head Up Display	V	V																			V																																	
R	2013	ALL	Body	Heated Seat Module	V	V																			V																																	
R	2013	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																	
R	2013	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																	
R	2013	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																	
R	2013	ALL	Body	Left Side Object Detection Module	V																			V	V																																	
R	2013	ALL	Body	Lift Gate Module	V	V																		V	V																																	
R	2013	ALL	Body	Park Assist Module	V	V																			V																																	
R	2013	ALL	Body	Passenger Door Switch	V	V																		V	V																																	
R	2013	ALL	Body	Passenger Presence System	V	V																			V																																	
R	2013	ALL	Body	Radio	V	V																		V	V																																	
R	2013	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																	
R	2013	ALL	Body	Right Side Object Detection Module	V																			V	V																																	
R	2013	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																	
R	2013	ALL	Body	Theft Deterrent Module	V	V																			V																																	
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V												
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V									V											
R	2014	Acadia	Powertrain	Chassis Control Module	V	V																		V	V							V		V																								
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																	
R	2014	Acadia	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																	
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																	
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
R	2014	Acadia	Body	Passenger Presence Module	V	V																			V																																	
R	2014	Acadia	Body	Instrument Cluster	V	V																		V	V																																	
R	2014	Acadia	Body	Head-Up Display Module	V	V																			V																																	
R	2014	Acadia	Body	Radio	V	V																		V	V																																	
R	2014	Acadia	Body	Rear Audio Control Module	V	V																			V																																	
R	2014	Acadia	Body	Digital Radio Receiver Control Module	V	V																		V	V																																	
R	2014	Acadia	Body	Personal Audio Link Control Module	V																				V																																	
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																	
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																	
R	2014	Acadia	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V											
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2014	Acadia	Body	Liftgate Control Module	V	V																			V																					V													
R	2014	Acadia	Body	Seat Memory Control Module	V	V																		V	V																																		
R	2014	Acadia	Body	Front Seat Heating Control Module	V	V																			V																																		
R	2014	Acadia	Body	Right Side Object Detection Control Module	V																			V	V																																		
R	2014	Acadia	Body	Left Side Object Detection Control Module	V																			V	V																																		
R	2014	Acadia	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
R	2014	Acadia	Body	Parking Assist Control Module	V																			V	V																																		
R	2014	Acadia	Body	Frontview Camera Module	V	V																		V	V																																		
R	2014	Acadia	Body	Theft Deterrent Module	V	V																			V																																		
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V													
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V									V												
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
R	2015	Acadia	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																		
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																		
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
R	2015	Acadia	Body	Passenger Presence Module	V	V																			V																																		
R	2015	Acadia	Body	Instrument Cluster	V	V																		V	V																																		
R	2015	Acadia	Body	Head-Up Display Module	V	V																		V	V																																		
R	2015	Acadia	Body	Radio	V	V																		V	V																																		
R	2015	Acadia	Body	Rear Audio Control Module	V	V																			V																																		
R	2015	Acadia	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
R	2015	Acadia	Body	Personal Audio Link Control Module	V																				V																																		
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																		
R	2015	Acadia	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V												
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
R	2015	Acadia	Body	Liftgate Control Module	V	V																			V																						V												
R	2015	Acadia	Body	Seat Memory Control Module	V	V																		V	V																																		
R	2015	Acadia	Body	Front Seat Heating Control Module	V	V																			V																																		
R	2015	Acadia	Body	Right Side Object Detection Control Module	V																			V	V																																		
R	2015	Acadia	Body	Left Side Object Detection Control Module	V																			V	V																																		
R	2015	Acadia	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
R	2015	Acadia	Body	Parking Assist Control Module	V																			V	V																																		
R	2015	Acadia	Body	Frontview Camera Module	V	V																		V	V																																		
R	2015	Acadia	Body	Theft Deterrent Module	V	V																			V																																		
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V								V	V	V	V		V													
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V									V												
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
R	2016	Acadia	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																		
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																		
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
R	2016	Acadia	Body	Passenger Presence Module	V	V																			V																																		
R	2016	Acadia	Body	Instrument Cluster	V	V																		V	V																																		
R	2016	Acadia	Body	Head-Up Display Module	V	V																		V	V																																		
R	2016	Acadia	Body	Radio	V	V																		V	V																																		
R	2016	Acadia	Body	Rear Audio Control Module	V	V																			V																																		
R	2016	Acadia	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
R	2016	Acadia	Body	Personal Audio Link Control Module	V																				V																																			
R	2016	Acadia	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
R	2016	Acadia	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V												
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																			
R	2016	Acadia	Body	Liftgate Control Module	V	V																			V																						V												
R	2016	Acadia	Body	Seat Memory Control Module	V	V																		V	V																																			
R	2016	Acadia	Body	Front Seat Heating Control Module	V	V																			V																																			
R	2016	Acadia	Body	Right Side Object Detection Control Module	V																			V	V																																			
R	2016	Acadia	Body	Left Side Object Detection Control Module	V																			V	V																																			
R	2016	Acadia	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
R	2016	Acadia	Body	Parking Assist Control Module	V																			V	V																																			
R	2016	Acadia	Body	Frontview Camera Module	V	V																		V	V																																			
R	2016	Acadia	Body	Theft Deterrent Module	V	V																			V																																			
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
S	2004	Sonoma	Chassis	4WAL 3 Sensor	V	V																		V																																			
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
S	2004	Sonoma	Body	Body Control Module	V	V																		V																																			
S	2004	Sonoma	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2004	Sonoma	Body	Base Radio	V	V																			V																																			
S	2004	Sonoma	Body	Uplevel Radio	V	V																			V																																			
S	2004	Sonoma	Body	Supplemental Inflatable Restraint	V	V																																																					
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module	V	V																		V											V	V																							
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module	V	V																		V											V	V																							
S	2004	Canyon	Chassis	ABS Without Traction Control	V	V																		V	V																																			
S	2004	Canyon	Chassis	ABS With Traction Control	V	V																		V	V																																			
S	2004	Canyon	Body	Body Control Module	V	V																		V	V																																			
S	2004	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2004	Canyon	Body	OnStar	V	V																		V	V																																			
S	2004	Canyon	Body	Base Radio	V	V																			V																																			
S	2004	Canyon	Body	Uplevel Radio	V	V																			V																																			
S	2004	Canyon	Body	Supplemental Inflatable Restraint	V	V																																																					
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																							
S	2004	Envoy	Chassis	ABS Without Traction Control	V	V																		V	V																																			
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																			
S	2004	Envoy	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
S	2004	Envoy	Body	Amplifier (Bose)	V	V																			V																																			
S	2004	Envoy	Body	Body Control Module	V																																																						
S	2004	Envoy	Body	Driver Door Module	V	V																		V	V																																			
S	2004	Envoy	Body	Driver Seat Module	V	V																		V	V																																			
S	2004	Envoy	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
S	2004	Envoy	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
S	2004	Envoy	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2004	Envoy	Body	Lift Gate Module	V	V																		V	V																																			
S	2004	Envoy	Body	OnStar	V	V																		V	V																																			
S	2004	Envoy	Body	Passenger Door Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2004	Envoy	Body	Uplevel Radio	V	V																			V																																				
S	2004	Envoy	Body	Navigation Radio	V	V																		V																																				
S	2004	Envoy	Body	Rear Seat Audio	V	V																			V																																			
S	2004	Envoy	Body	Rear Seat Entertainment	V																				V																																			
S	2004	Envoy	Body	Supplemental Inflatable Restraint	V	V																																																						
S	2004	Envoy	Body	Vehicle Theft Deterrent	V	V																																																						
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																								
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module	V	V																		V											V	V																								
S	2004	Envoy XL	Chassis	ABS Without Traction Control	V	V																		V	V																																			
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																				
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
S	2004	Envoy XL	Body	Amplifier (Bose)	V	V																			V																																				
S	2004	Envoy XL	Body	Body Control Module	V																																																							
S	2004	Envoy XL	Body	Driver Door Module	V	V																		V	V																																			
S	2004	Envoy XL	Body	Driver Seat Module	V	V																		V	V																																			
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
S	2004	Envoy XL	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2004	Envoy XL	Body	Lift Gate Module	V	V																		V	V																																			
S	2004	Envoy XL	Body	OnStar	V	V																		V	V																																			
S	2004	Envoy XL	Body	Passenger Door Module	V	V																		V	V																																			
S	2004	Envoy XL	Body	Uplevel Radio	V	V																			V																																			
S	2004	Envoy XL	Body	Navigation Radio	V	V																		V																																				
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto	V	V																		V	V																																			
S	2004	Envoy XL	Body	Rear HVAC Manual	V	V																		V	V																																			
S	2004	Envoy XL	Body	Rear Seat Entertainment	V																				V																																			
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint	V	V																																																					
S	2004	Envoy XL	Body	Vehicle Theft Deterrent	V	V																																																					
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																								
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module	V	V										V	V				V	V		V	V							V														V													
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module	V	V																		V											V	V																								
S	2004	Envoy XUV	Chassis	ABS Without Traction Control	V	V																		V	V																																			
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																				
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
S	2004	Envoy XUV	Body	Amplifier (Bose)	V	V																			V																																				
S	2004	Envoy XUV	Body	Body Control Module	V																																																							
S	2004	Envoy XUV	Body	Driver Door Module	V	V																		V	V																																			
S	2004	Envoy XUV	Body	Driver Seat Module	V	V																		V	V																																			
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
S	2004	Envoy XUV	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2004	Envoy XUV	Body	Lift Gate Module	V	V																		V	V																																			
S	2004	Envoy XUV	Body	OnStar	V	V																		V	V																																			
S	2004	Envoy XUV	Body	Passenger Door Module	V	V																		V	V																																			
S	2004	Envoy XUV	Body	Uplevel Radio	V	V																			V																																			
S	2004	Envoy XUV	Body	Navigation Radio	V	V																		V																																				
S	2004	Envoy XUV	Body	Rear Seat Audio	V	V																			V																																			
S	2004	Envoy XUV	Body	Rear Seat Entertainment	V																				V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint	V	V																																																									
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent	V	V																																																								
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V															
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																										
S	2004	Jimmy	Chassis	4WAL 3 Sensor	V	V																		V																																					
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)	V	V																		V																																					
S	2004	Jimmy	Body	Body Control Module	V	V																		V																																					
S	2004	Jimmy	Body	Heating and Air Conditioning	V	V																		V	V																																				
S	2004	Jimmy	Body	Instrument Panel Cluster	V	V																		V	V																																				
S	2004	Jimmy	Body	Memory Seat Module	V	V																			V																																				
S	2004	Jimmy	Body	Base Radio	V	V																			V																																				
S	2004	Jimmy	Body	Uplevel Radio	V	V																			V																																				
S	2004	Jimmy	Body	Supplemental Inflatable Restraint	V	V																																																							
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module	V	V							V			V					V	V		V	V							V														V															
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module	V	V																		V											V	V																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module	V	V							V			V					V	V		V	V							V														V															
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module	V	V																		V											V	V																										
S	2005	Canyon	Chassis	ABS Without Traction Control	V	V																		V	V																																				
S	2005	Canyon	Chassis	ABS With Traction Control	V	V																		V	V																																				
S	2005	Canyon	Body	Body Control Module	V	V																		V	V																																				
S	2005	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																				
S	2005	Canyon	Body	Base Radio	V	V																			V																																				
S	2005	Canyon	Body	Uplevel Radio	V	V																			V																																				
S	2005	Canyon	Body	Supplemental Inflatable Restraint	V	V																																																						
S	2005	Canyon	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V														V															
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																										
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V															
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V											V	V																										
S	2005	Envoy	Chassis	ABS Without Traction Control	V	V																		V	V																																				
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																					
S	2005	Envoy	Chassis	Traction Assist (If Equipped)	V	V																		V																																					
S	2005	Envoy	Body	Body Control Module	V																																																							
S	2005	Envoy	Body	Disc Player and Video Display	V																				V																																				
S	2005	Envoy	Body	Driver Door Module	V	V																		V	V																																				
S	2005	Envoy	Body	Driver Seat Module	V	V																		V	V																																				
S	2005	Envoy	Body	Heating and Air Conditioning Auto	V	V																		V	V																																				
S	2005	Envoy	Body	Heating and Air Conditioning Manual	V	V																		V	V																																				
S	2005	Envoy	Body	Instrument Panel Cluster	V	V																		V	V																																				
S	2005	Envoy	Body	Lift Gate Module	V	V																		V	V																																				
S	2005	Envoy	Body	Passenger Door Module	V	V																		V	V																																				
S	2005	Envoy	Body	Passenger Presence System																																																								
S	2005	Envoy	Body	Uplevel Radio	V	V																			V																																				
S	2005	Envoy	Body	Navigation Radio	V	V																		V																																				
S	2005	Envoy	Body	Rear Seat Audio	V	V																			V																																				
S	2005	Envoy	Body	Supplemental Inflatable Restraint	V	V																			V																																				
S	2005	Envoy	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
S	2005	Envoy	Body	Vehicle Theft Deterrent	V	V																																																						
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V														V															
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																										
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V															

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V											V	V																								
S	2005	Envoy XL	Chassis	ABS Without Traction Control	V	V																		V	V																																		
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																			
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
S	2005	Envoy XL	Body	Body Control Module	V																																																					
S	2005	Envoy XL	Body	Disc Player and Video Display	V																				V																																	
S	2005	Envoy XL	Body	Driver Door Module	V	V																		V	V																																	
S	2005	Envoy XL	Body	Driver Seat Module	V	V																		V	V																																	
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																	
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																	
S	2005	Envoy XL	Body	Instrument Panel Cluster	V	V																		V	V																																	
S	2005	Envoy XL	Body	Lift Gate Module	V	V																		V	V																																	
S	2005	Envoy XL	Body	Passenger Door Module	V	V																		V	V																																	
S	2005	Envoy XL	Body	Passenger Presence System																																																						
S	2005	Envoy XL	Body	Uplevel Radio	V	V																			V																																	
S	2005	Envoy XL	Body	Navigation Radio	V	V																		V																																		
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto	V	V																		V	V																																	
S	2005	Envoy XL	Body	Rear HVAC Manual	V	V																		V	V																																	
S	2005	Envoy XL	Body	Rear Seat Audio	V	V																			V																																	
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint	V	V																			V																																	
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																	
S	2005	Envoy XL	Body	Vehicle Theft Deterrent	V	V																																																			
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V														V												
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																							
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V												
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V											V	V																							
S	2005	Envoy XUV	Chassis	ABS Without Traction Control	V	V																		V	V																																		
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																			
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
S	2005	Envoy XUV	Body	Body Control Module	V																																																				
S	2005	Envoy XUV	Body	Disc Player and Video Display	V																				V																																	
S	2005	Envoy XUV	Body	Driver Door Module	V	V																		V	V																																	
S	2005	Envoy XUV	Body	Driver Seat Module	V	V																		V	V																																	
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto	V	V																		V	V																																	
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual	V	V																		V	V																																	
S	2005	Envoy XUV	Body	Instrument Panel Cluster	V	V																		V	V																																	
S	2005	Envoy XUV	Body	Lift Gate Module	V	V																		V	V																																	
S	2005	Envoy XUV	Body	Passenger Door Module	V	V																		V	V																																	
S	2005	Envoy XUV	Body	Passenger Presence System																																																					
S	2005	Envoy XUV	Body	Uplevel Radio	V	V																			V																																	
S	2005	Envoy XUV	Body	Navigation Radio	V	V																		V																																		
S	2005	Envoy XUV	Body	Rear Seat Audio	V	V																			V																																	
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint	V	V																			V																																	
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module	V	V																		V	V																																	
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent	V	V																																																			
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V												
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
S	2005	Jimmy	Chassis	4WAL 3 Sensor	V	V																		V																																			
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
S	2005	Jimmy	Body	Body Control Module	V	V																		V																																			
S	2005	Jimmy	Body	Heating and Air Conditioning	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2005	Jimmy	Body	Instrument Panel Cluster	V	V																		V	V																																				
S	2005	Jimmy	Body	Memory Seat Module	V	V																			V																																				
S	2005	Jimmy	Body	Base Radio	V	V																			V																																				
S	2005	Jimmy	Body	Uplevel Radio	V	V																			V																																				
S	2005	Jimmy	Body	Supplemental Inflatable Restraint	V	V																																																						
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V														
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																									
S	2005	Sonoma	Chassis	4WAL 3 Sensor	V	V																		V																																				
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
S	2005	Sonoma	Body	Body Control Module	V	V																		V																																				
S	2005	Sonoma	Body	Instrument Panel Cluster	V	V																		V	V																																				
S	2005	Sonoma	Body	Base Radio	V	V																			V																																				
S	2005	Sonoma	Body	Uplevel Radio	V	V																			V																																				
S	2005	Sonoma	Body	Supplemental Inflatable Restraint	V	V																																																						
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module	V	V							V			V					V	V		V	V							V														V														
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module	V	V																		V											V	V																									
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module	V	V							V			V					V	V		V	V							V														V														
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module	V	V																		V											V	V																									
S	2006	Canyon	Chassis	ABS Without Traction Control	V	V																		V	V																																				
S	2006	Canyon	Chassis	ABS With Traction Control	V	V																		V	V																																				
S	2006	Canyon	Body	Body Control Module	V	V																		V	V																																				
S	2006	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																				
S	2006	Canyon	Body	Passenger Presence System																																																								
S	2006	Canyon	Body	Base Radio	V	V																			V																																				
S	2006	Canyon	Body	Uplevel Radio	V	V																			V																																				
S	2006	Canyon	Body	Supplemental Inflatable Restraint	V	V																																																						
S	2006	Canyon	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V														V														
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																									
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V														
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V											V	V																									
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V														
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V											V	V																									
S	2006	Envoy	Chassis	ABS/TCS/VSES	V	V																		V	V																																				
S	2006	Envoy	Chassis	Tire Pressure Monitor	V	V																		V																																				
S	2006	Envoy	Body	Body Control Module	V	V																		V	V																																				
S	2006	Envoy	Body	Disc Player and Video Display	V																				V																																				
S	2006	Envoy	Body	Driver Door Module	V	V																		V	V																																				
S	2006	Envoy	Body	Driver Seat Module	V	V																		V	V																																				
S	2006	Envoy	Body	Heating and Air Conditioning Auto	V	V																		V	V																																				
S	2006	Envoy	Body	Heating and Air Conditioning Manual	V	V																		V	V																																				
S	2006	Envoy	Body	Instrument Panel Cluster	V	V																		V	V																																				
S	2006	Envoy	Body	Lift Gate Module	V	V																		V	V																																				
S	2006	Envoy	Body	Passenger Door Module	V	V																		V	V																																				
S	2006	Envoy	Body	Passenger Presence System																																																								
S	2006	Envoy	Body	Uplevel Radio	V	V																			V																																				
S	2006	Envoy	Body	Navigation Radio	V	V																		V																																				
S	2006	Envoy	Body	Rear Seat Audio	V	V																			V																																				
S	2006	Envoy	Body	Supplemental Inflatable Restraint	V	V																			V																																				
S	2006	Envoy	Body	Vehicle Theft Deterrent	V	V																																																						
S	2006	Envoy	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V													V														
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																								
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V											V	V																								
S	2006	Envoy XL	Chassis	ABS/TCS/VSES	V	V																		V	V																																		
S	2006	Envoy XL	Body	Body Control Module	V	V																		V	V																																		
S	2006	Envoy XL	Body	Disc Player and Video Display	V																				V																																		
S	2006	Envoy XL	Body	Driver Door Module	V	V																		V	V																																		
S	2006	Envoy XL	Body	Driver Seat Module	V	V																		V	V																																		
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																		
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																		
S	2006	Envoy XL	Body	Instrument Panel Cluster	V	V																		V	V																																		
S	2006	Envoy XL	Body	Lift Gate Module	V	V																		V	V																																		
S	2006	Envoy XL	Body	Passenger Door Module	V	V																		V	V																																		
S	2006	Envoy XL	Body	Passenger Presence System																																																							
S	2006	Envoy XL	Body	Uplevel Radio	V	V																			V																																		
S	2006	Envoy XL	Body	Navigation Radio	V	V																		V																																		
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto	V	V																		V	V																																		
S	2006	Envoy XL	Body	Rear HVAC Manual	V	V																		V	V																																		
S	2006	Envoy XL	Body	Rear Seat Audio	V	V																			V																																		
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
S	2006	Envoy XL	Body	Vehicle Theft Deterrent	V	V																																																				
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V						V			V	V	V			V	V		V								V													V														
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V											V	V																							
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V						V			V	V	V			V	V		V								V													V														
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V											V	V																							
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control	V	V																		V	V																																		
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control	V	V																		V	V																																		
S	2007	Canyon	Body	Body Control Module	V	V																		V	V																																		
S	2007	Canyon	Body	Digital Radio Receiver	V	V																			V																																		
S	2007	Canyon	Body	Generator Battery Control Module	V	V																		V	V																																		
S	2007	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																		
S	2007	Canyon	Body	Passenger Presence System																																																						
S	2007	Canyon	Body	Base Radio	V	V																			V																																		
S	2007	Canyon	Body	Uplevel Radio	V	V																			V																																		
S	2007	Canyon	Body	Supplemental Inflatable Restraint	V	V																																																				
S	2007	Canyon	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V	V						V			V	V	V			V	V		V								V													V														
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																							
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module	V	V	V						V			V	V	V			V	V		V								V													V														
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module	V	V																		V											V	V																							
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V											V	V																							
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V											V	V																							
S	2007	Envoy	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
S	2007	Envoy	Body	Body Control Module	V	V																		V	V																																		
S	2007	Envoy	Body	Digital Radio Receiver	V	V																			V																																		
S	2007	Envoy	Body	Disc Player and Video Display	V																				V																																		
S	2007	Envoy	Body	Driver Door Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2007	Envoy	Body	Driver Seat Module	V	V																		V	V																																			
S	2007	Envoy	Body	Generator Battery Control Module	V	V																		V	V																																			
S	2007	Envoy	Body	HVAC Control Module Auto	V	V																		V	V																																			
S	2007	Envoy	Body	HVAC Control Module Manual	V	V																		V	V																																			
S	2007	Envoy	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2007	Envoy	Body	Lift Gate Module	V	V																		V	V																																			
S	2007	Envoy	Body	Passenger Door Module	V	V																		V	V																																			
S	2007	Envoy	Body	Passenger Presence System																																																								
S	2007	Envoy	Body	Uplevel Radio	V	V																			V																																			
S	2007	Envoy	Body	Navigation Radio	V	V																		V																																				
S	2007	Envoy	Body	Rear Seat Audio	V	V																			V																																			
S	2007	Envoy	Body	Supplemental Inflatable Restraint	V	V																			V																																			
S	2007	Envoy	Body	Theft Deterrent Module	V	V																																																						
S	2007	Envoy	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																									
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																									
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control	V	V																		V	V																																			
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control	V	V																		V	V																																			
S	2008	Canyon	Body	Body Control Module	V	V																		V	V																																			
S	2008	Canyon	Body	Digital Radio Receiver	V	V																			V																																			
S	2008	Canyon	Body	Generator Battery Control Module	V	V																		V	V																																			
S	2008	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2008	Canyon	Body	Passenger Presence System																																																								
S	2008	Canyon	Body	Base Radio	V	V																			V																																			
S	2008	Canyon	Body	Uplevel Radio	V	V																			V																																			
S	2008	Canyon	Body	Supplemental Inflatable Restraint	V	V																																																						
S	2008	Canyon	Body	Theft Deterrent Module	V	V																																																						
S	2008	Canyon	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																									
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																									
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																									
S	2008	Envoy	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
S	2008	Envoy	Body	Body Control Module	V	V																		V	V																																			
S	2008	Envoy	Body	Digital Radio Receiver	V	V																			V																																			
S	2008	Envoy	Body	Disc Player and Video Display	V																				V																																			
S	2008	Envoy	Body	Driver Door Module	V	V																		V	V																																			
S	2008	Envoy	Body	Driver Seat Module	V	V																		V	V																																			
S	2008	Envoy	Body	Generator Battery Control Module	V	V																		V	V																																			
S	2008	Envoy	Body	HVAC Control Module Auto	V	V																		V	V																																			
S	2008	Envoy	Body	HVAC Control Module Manual	V	V																		V	V																																			
S	2008	Envoy	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2008	Envoy	Body	Lift Gate Module	V	V																		V	V																																			
S	2008	Envoy	Body	Passenger Door Module	V	V																		V	V																																			
S	2008	Envoy	Body	Passenger Presence System																																																								
S	2008	Envoy	Body	Uplevel Radio	V	V																			V																																			
S	2008	Envoy	Body	Navigation Radio	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Right Front Solenoid Valves	ABS Left Front Solenoid Valves	ABS Right Rear Solenoid Valves	ABS Left Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2008	Envoy	Body	Rear Seat Audio	V	V																			V																																			
S	2008	Envoy	Body	Supplemental Inflatable Restraint	V	V																			V																																			
S	2008	Envoy	Body	Theft Deterrent Module	V	V																																																						
S	2008	Envoy	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																									
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																			
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																									
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																			
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V														
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module	V	V																		V										V	V																									
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module	V	V																		V	V																																			
S	2009	Canyon	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
S	2009	Canyon	Body	Body Control Module	V	V																		V	V																																			
S	2009	Canyon	Body	Digital Radio Receiver	V	V																		V	V																																			
S	2009	Canyon	Body	Generator Battery Control Module	V	V																		V	V																																			
S	2009	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2009	Canyon	Body	Passenger Presence System																																																							
S	2009	Canyon	Body	Base Radio	V	V																			V																																			
S	2009	Canyon	Body	Uplevel Radio	V	V																			V																																			
S	2009	Canyon	Body	Supplemental Inflatable Restraint	V	V																																																					
S	2009	Canyon	Body	Theft Deterrent Module	V	V																																																					
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																									
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module	V	V																		V	V																																			
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																									
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module	V	V																		V	V																																			
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																									
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module	V	V																		V	V																																			
S	2009	Envoy	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
S	2009	Envoy	Body	Body Control Module	V	V																		V	V																																			
S	2009	Envoy	Body	Digital Radio Receiver	V	V																		V	V																																			
S	2009	Envoy	Body	Disc Player and Video Display	V																				V																																			
S	2009	Envoy	Body	Driver Door Module	V	V																		V	V																																			
S	2009	Envoy	Body	Driver Seat Module	V	V																		V	V																																			
S	2009	Envoy	Body	Generator Battery Control Module	V	V																		V	V																																			
S	2009	Envoy	Body	HVAC Control Module Auto	V	V																		V	V																																			
S	2009	Envoy	Body	HVAC Control Module Manual	V	V																		V	V																																			
S	2009	Envoy	Body	Instrument Panel Cluster	V	V																		V	V																																			
S	2009	Envoy	Body	Lift Gate Module	V	V																		V	V																																			
S	2009	Envoy	Body	Passenger Door Module	V	V																		V	V																																			
S	2009	Envoy	Body	Passenger Presence System																																																							
S	2009	Envoy	Body	Uplevel Radio	V	V																			V																																			
S	2009	Envoy	Body	Navigation Radio	V	V																		V																																			
S	2009	Envoy	Body	Rear Seat Audio	V	V																			V																																			
S	2009	Envoy	Body	Supplemental Inflatable Restraint	V	V																			V																																			
S	2009	Envoy	Body	Theft Deterrent Module	V	V																																																					
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V											V	V																									
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																			
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V											V	V																									
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																			
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module	V	V																		V											V	V																									
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																			
S	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
S	2010	ALL	Body	Body Control Module	V	V																		V	V																																			
S	2010	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
S	2010	ALL	Body	Generator Battery Control Module	V	V																		V	V																																			
S	2010	ALL	Body	Instument Panel Cluster	V	V																		V	V																																			
S	2010	ALL	Body	Passenger Presence System																																																							
S	2010	ALL	Body	Personal Audio Link Module	V																				V																																			
S	2010	ALL	Body	Base Radio	V	V																			V																																			
S	2010	ALL	Body	Uplevel Radio	V	V																			V																																			
S	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
S	2010	ALL	Body	Theft Deterrent Module	V	V																																																					
S	2010	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V						V														V														
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display	V	V																		V																																				
T	2004	Sonoma	Chassis	4WAL 3 Sensor	V	V																		V																																				
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
T	2004	Sonoma	Body	Body Control Module	V	V																		V																																				
T	2004	Sonoma	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2004	Sonoma	Body	Base Radio	V	V																			V																																			
T	2004	Sonoma	Body	Uplevel Radio	V	V																			V																																			
T	2004	Sonoma	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module	V	V							V			V					V	V		V	V						V														V														
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module	V	V																		V											V	V																									
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module	V	V							V			V					V	V		V	V						V														V														
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module	V	V																		V											V	V																									
T	2004	Canyon	Chassis	ABS Without Traction Control	V	V																		V	V																																			
T	2004	Canyon	Chassis	ABS With Traction Control	V	V																		V	V																																			
T	2004	Canyon	Body	Body Control Module	V	V																		V	V																																			
T	2004	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2004	Canyon	Body	OnStar	V	V																		V	V																																			
T	2004	Canyon	Body	Base Radio	V	V																			V																																			
T	2004	Canyon	Body	Uplevel Radio	V	V																			V																																			
T	2004	Canyon	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2004	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V						V														V														
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active	V	V																		V																																				
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable	V	V																		V																																				
T	2004	Envoy	Chassis	ABS Without Traction Control	V	V																		V	V																																			
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																				
T	2004	Envoy	Chassis	Traction Assist (If Equipped)	V	V																		V																																				
T	2004	Envoy	Body	Amplifier (Bose)	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2004	Envoy	Body	Body Control Module	V																																																							
T	2004	Envoy	Body	Driver Door Module	V	V																		V	V																																			
T	2004	Envoy	Body	Driver Seat Module	V	V																		V	V																																			
T	2004	Envoy	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
T	2004	Envoy	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
T	2004	Envoy	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2004	Envoy	Body	Lift Gate Module	V	V																		V	V																																			
T	2004	Envoy	Body	OnStar	V	V																		V	V																																			
T	2004	Envoy	Body	Passenger Door Module	V	V																		V	V																																			
T	2004	Envoy	Body	Uplevel Radio	V	V																			V																																			
T	2004	Envoy	Body	Navigation Radio	V	V																		V																																			
T	2004	Envoy	Body	Rear Seat Audio	V	V																			V																																		
T	2004	Envoy	Body	Rear Seat Entertainment	V																				V																																			
T	2004	Envoy	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2004	Envoy	Body	Vehicle Theft Deterrent	V	V																																																					
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V						V														V														
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																								
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display	V	V																		V																																			
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module	V	V										V	V				V	V		V	V						V														V														
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module	V	V																		V										V	V																								
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display	V	V																		V																																			
T	2004	Envoy XL	Chassis	ABS Without Traction Control	V	V																		V	V																																			
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																			
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
T	2004	Envoy XL	Body	Amplifier (Bose)	V	V																			V																																			
T	2004	Envoy XL	Body	Body Control Module	V																																																						
T	2004	Envoy XL	Body	Driver Door Module	V	V																		V	V																																			
T	2004	Envoy XL	Body	Driver Seat Module	V	V																		V	V																																			
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
T	2004	Envoy XL	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2004	Envoy XL	Body	Lift Gate Module	V	V																		V	V																																			
T	2004	Envoy XL	Body	OnStar	V	V																		V	V																																			
T	2004	Envoy XL	Body	Passenger Door Module	V	V																		V	V																																			
T	2004	Envoy XL	Body	Uplevel Radio	V	V																			V																																			
T	2004	Envoy XL	Body	Navigation Radio	V	V																		V																																			
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto	V	V																		V	V																																			
T	2004	Envoy XL	Body	Rear HVAC Manual	V	V																		V	V																																			
T	2004	Envoy XL	Body	Rear Seat Entertainment	V																				V																																			
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2004	Envoy XL	Body	Vehicle Theft Deterrent	V	V																																																					
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V						V														V														
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																								
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display	V	V																		V																																			
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module	V	V										V	V				V	V		V	V						V														V														
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module	V	V																		V										V	V																								
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display	V	V																		V																																			
T	2004	Envoy XUV	Chassis	ABS Without Traction Control	V	V																		V	V																																			
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																			
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
T	2004	Envoy XUV	Body	Amplifier (Bose)	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2004	Envoy XUV	Body	Body Control Module	V																																																							
T	2004	Envoy XUV	Body	Driver Door Module	V	V																		V	V																																			
T	2004	Envoy XUV	Body	Driver Seat Module	V	V																		V	V																																			
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual	V	V																		V	V																																			
T	2004	Envoy XUV	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2004	Envoy XUV	Body	Lift Gate Module	V	V																		V	V																																			
T	2004	Envoy XUV	Body	OnStar	V	V																		V	V																																			
T	2004	Envoy XUV	Body	Passenger Door Module	V	V																		V	V																																			
T	2004	Envoy XUV	Body	Uplevel Radio	V	V																			V																																			
T	2004	Envoy XUV	Body	Navigation Radio	V	V																		V																																				
T	2004	Envoy XUV	Body	Rear Seat Audio	V	V																			V																																			
T	2004	Envoy XUV	Body	Rear Seat Entertainment	V																				V																																			
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent	V	V																																																					
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V						V														V														
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display	V	V																		V																																			
T	2004	Jimmy	Chassis	4WAL 3 Sensor	V	V																		V																																			
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
T	2004	Jimmy	Body	Body Control Module	V	V																		V																																			
T	2004	Jimmy	Body	Heating and Air Conditioning	V	V																		V	V																																			
T	2004	Jimmy	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2004	Jimmy	Body	Memory Seat Module	V	V																			V																																			
T	2004	Jimmy	Body	Base Radio	V	V																			V																																			
T	2004	Jimmy	Body	Uplevel Radio	V	V																			V																																			
T	2004	Jimmy	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module	V	V							V			V					V	V		V	V						V														V														
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module	V	V																		V										V	V																								
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module	V	V							V			V					V	V		V	V						V														V														
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module	V	V																		V										V	V																								
T	2005	Canyon	Chassis	ABS Without Traction Control	V	V																		V	V																																			
T	2005	Canyon	Chassis	ABS With Traction Control	V	V																		V	V																																			
T	2005	Canyon	Body	Body Control Module	V	V																		V	V																																			
T	2005	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2005	Canyon	Body	Base Radio	V	V																			V																																			
T	2005	Canyon	Body	Uplevel Radio	V	V																			V																																			
T	2005	Canyon	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2005	Canyon	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V						V														V														
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																								
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active	V	V																		V																																			
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable	V	V										V	V				V			V	V						V														V														
T	2005	Envoy	Chassis	ABS Without Traction Control	V	V																		V	V																																			
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																			
T	2005	Envoy	Chassis	Traction Assist (If Equipped)	V	V																		V																																			
T	2005	Envoy	Body	Body Control Module	V																																																						
T	2005	Envoy	Body	Disc Player and Video Display	V																				V																																			
T	2005	Envoy	Body	Driver Door Module	V	V																		V	V																																			
T	2005	Envoy	Body	Driver Seat Module	V	V																		V	V																																			
T	2005	Envoy	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2005	Envoy	Body	Heating and Air Conditioning Manual	V	V																		V	V																																					
T	2005	Envoy	Body	Instrument Panel Cluster	V	V																		V	V																																					
T	2005	Envoy	Body	Lift Gate Module	V	V																		V	V																																					
T	2005	Envoy	Body	Passenger Door Module	V	V																		V	V																																					
T	2005	Envoy	Body	Passenger Presence System																																																									
T	2005	Envoy	Body	Uplevel Radio	V	V																			V																																					
T	2005	Envoy	Body	Navigation Radio	V	V																		V																																					
T	2005	Envoy	Body	Rear Seat Audio	V	V																			V																																					
T	2005	Envoy	Body	Supplemental Inflatable Restraint	V	V																			V																																					
T	2005	Envoy	Body	Vehicle Comm. Interface Module	V	V																		V	V																																					
T	2005	Envoy	Body	Vehicle Theft Deterrent	V	V																																																							
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V						V														V																
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display	V	V																		V																																					
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V						V														V																
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display	V	V																		V																																					
T	2005	Envoy XL	Chassis	ABS Without Traction Control	V	V																		V	V																																					
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																					
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)	V	V																		V																																					
T	2005	Envoy XL	Body	Body Control Module	V																																																								
T	2005	Envoy XL	Body	Disc Player and Video Display	V																				V																																					
T	2005	Envoy XL	Body	Driver Door Module	V	V																		V	V																																					
T	2005	Envoy XL	Body	Driver Seat Module	V	V																		V	V																																					
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																					
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																					
T	2005	Envoy XL	Body	Instrument Panel Cluster	V	V																		V	V																																					
T	2005	Envoy XL	Body	Lift Gate Module	V	V																		V	V																																					
T	2005	Envoy XL	Body	Passenger Door Module	V	V																		V	V																																					
T	2005	Envoy XL	Body	Passenger Presence System																																																									
T	2005	Envoy XL	Body	Uplevel Radio	V	V																			V																																					
T	2005	Envoy XL	Body	Navigation Radio	V	V																		V																																					
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto	V	V																		V	V																																					
T	2005	Envoy XL	Body	Rear HVAC Manual	V	V																		V	V																																					
T	2005	Envoy XL	Body	Rear Seat Audio	V	V																			V																																					
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint	V	V																			V																																					
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																					
T	2005	Envoy XL	Body	Vehicle Theft Deterrent	V	V																																																							
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V						V														V																
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display	V	V																		V																																					
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V						V														V																
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display	V	V																		V																																					
T	2005	Envoy XUV	Chassis	ABS Without Traction Control	V	V																		V	V																																					
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control	V	V																		V																																					
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)	V	V																		V																																					
T	2005	Envoy XUV	Body	Body Control Module	V																																																							
T	2005	Envoy XUV	Body	Disc Player and Video Display	V																				V																																					
T	2005	Envoy XUV	Body	Driver Door Module	V	V																		V	V																																					
T	2005	Envoy XUV	Body	Driver Seat Module	V	V																		V	V																																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto	V	V																		V	V																																			
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual	V	V																		V	V																																		
T	2005	Envoy XUV	Body	Instrument Panel Cluster	V	V																		V	V																																		
T	2005	Envoy XUV	Body	Lift Gate Module	V	V																		V	V																																		
T	2005	Envoy XUV	Body	Passenger Door Module	V	V																		V	V																																		
T	2005	Envoy XUV	Body	Passenger Presence System																																																							
T	2005	Envoy XUV	Body	Uplevel Radio	V	V																			V																																		
T	2005	Envoy XUV	Body	Navigation Radio	V	V																		V																																		
T	2005	Envoy XUV	Body	Rear Seat Audio	V	V																			V																																		
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint	V	V																			V																																		
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent	V	V																																																					
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																						
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display	V	V																		V																																		
T	2005	Jimmy	Chassis	4WAL 3 Sensor	V	V																		V																																		
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)	V	V																		V																																		
T	2005	Jimmy	Body	Body Control Module	V	V																		V																																		
T	2005	Jimmy	Body	Heating and Air Conditioning	V	V																		V	V																																		
T	2005	Jimmy	Body	Instrument Panel Cluster	V	V																		V	V																																		
T	2005	Jimmy	Body	Memory Seat Module	V	V																			V																																		
T	2005	Jimmy	Body	Base Radio	V	V																			V																																		
T	2005	Jimmy	Body	Uplevel Radio	V	V																			V																																		
T	2005	Jimmy	Body	Supplemental Inflatable Restraint	V	V																																																				
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V										V	V				V			V	V							V														V													
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																						
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display	V	V																		V																																		
T	2005	Sonoma	Chassis	4WAL 3 Sensor	V	V																		V																																		
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)	V	V																		V																																		
T	2005	Sonoma	Body	Body Control Module	V	V																		V																																		
T	2005	Sonoma	Body	Instrument Panel Cluster	V	V																		V	V																																		
T	2005	Sonoma	Body	Base Radio	V	V																			V																																		
T	2005	Sonoma	Body	Uplevel Radio	V	V																			V																																		
T	2005	Sonoma	Body	Supplemental Inflatable Restraint	V	V																																																				
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module	V	V																		V											V	V																						
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module	V	V																		V											V	V																						
T	2006	Canyon	Chassis	ABS Without Traction Control	V	V																		V	V																																		
T	2006	Canyon	Chassis	ABS With Traction Control	V	V																		V	V																																		
T	2006	Canyon	Body	Body Control Module	V	V																		V	V																																		
T	2006	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																		
T	2006	Canyon	Body	Passenger Presence System																																																						
T	2006	Canyon	Body	Base Radio	V	V																			V																																		
T	2006	Canyon	Body	Uplevel Radio	V	V																			V																																		
T	2006	Canyon	Body	Supplemental Inflatable Restraint	V	V																																																				
T	2006	Canyon	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V											V	V																						
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display	V	V																		V																																		
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																										
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display	V	V																		V																																					
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V														
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																										
T	2006	Envoy	Chassis	ABS/TCS/VSES	V	V																		V	V																																				
T	2006	Envoy	Chassis	Tire Pressure Monitor	V	V																		V																																					
T	2006	Envoy	Body	Body Control Module	V	V																		V	V																																				
T	2006	Envoy	Body	Disc Player and Video Display	V																				V																																				
T	2006	Envoy	Body	Driver Door Module	V	V																		V	V																																				
T	2006	Envoy	Body	Driver Seat Module	V	V																		V	V																																				
T	2006	Envoy	Body	Heating and Air Conditioning Auto	V	V																		V	V																																				
T	2006	Envoy	Body	Heating and Air Conditioning Manual	V	V																		V	V																																				
T	2006	Envoy	Body	Instrument Panel Cluster	V	V																		V	V																																				
T	2006	Envoy	Body	Lift Gate Module	V	V																		V	V																																				
T	2006	Envoy	Body	Passenger Door Module	V	V																		V	V																																				
T	2006	Envoy	Body	Passenger Presence System																																																								
T	2006	Envoy	Body	Uplevel Radio	V	V																			V																																				
T	2006	Envoy	Body	Navigation Radio	V	V																		V																																				
T	2006	Envoy	Body	Rear Seat Audio	V	V																			V																																			
T	2006	Envoy	Body	Supplemental Inflatable Restraint	V	V																			V																																			
T	2006	Envoy	Body	Vehicle Theft Deterrent	V	V																																																					
T	2006	Envoy	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V							V			V					V	V		V	V							V														V													
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																									
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display	V	V																		V																																				
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V													
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																									
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display	V	V																		V																																				
T	2006	Envoy XL	Chassis	ABS/TCS/VSES	V	V																		V	V																																				
T	2006	Envoy XL	Body	Body Control Module	V	V																		V	V																																				
T	2006	Envoy XL	Body	Disc Player and Video Display	V																				V																																				
T	2006	Envoy XL	Body	Driver Door Module	V	V																		V	V																																				
T	2006	Envoy XL	Body	Driver Seat Module	V	V																		V	V																																				
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto	V	V																		V	V																																				
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual	V	V																		V	V																																				
T	2006	Envoy XL	Body	Instrument Panel Cluster	V	V																		V	V																																				
T	2006	Envoy XL	Body	Lift Gate Module	V	V																		V	V																																				
T	2006	Envoy XL	Body	Passenger Door Module	V	V																		V	V																																				
T	2006	Envoy XL	Body	Passenger Presence System																																																								
T	2006	Envoy XL	Body	Uplevel Radio	V	V																			V																																				
T	2006	Envoy XL	Body	Navigation Radio	V	V																		V																																				
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto	V	V																		V	V																																				
T	2006	Envoy XL	Body	Rear HVAC Manual	V	V																		V	V																																				
T	2006	Envoy XL	Body	Rear Seat Audio	V	V																			V																																				
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint	V	V																			V																																				
T	2006	Envoy XL	Body	Vehicle Theft Deterrent	V	V																																																					
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V						V			V	V	V			V	V		V								V														V													
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																									
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module	V																			V																																				
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V						V			V	V	V			V	V		V								V														V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																									
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module	V																			V																																				
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control	V	V																		V	V																																			
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control	V	V																		V	V																																			
T	2007	Canyon	Body	Body Control Module	V	V																		V	V																																			
T	2007	Canyon	Body	Digital Radio Receiver	V	V																			V																																			
T	2007	Canyon	Body	Generator Battery Control Module	V	V																		V	V																																			
T	2007	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2007	Canyon	Body	Passenger Presence System	V																																																						
T	2007	Canyon	Body	Base Radio	V	V																			V																																			
T	2007	Canyon	Body	Uplevel Radio	V	V																			V																																			
T	2007	Canyon	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2007	Canyon	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V	V						V			V	V	V			V	V		V								V														V													
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																								
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module	V	V																		V																																				
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module	V	V	V						V			V	V	V			V	V		V								V														V													
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module	V	V																		V										V	V																								
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module	V	V																		V																																				
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																					V													
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																								
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																		V																																				
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																					V													
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																								
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module	V	V																		V																																				
T	2007	Envoy	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
T	2007	Envoy	Body	Body Control Module	V	V																		V	V																																			
T	2007	Envoy	Body	Digital Radio Receiver	V	V																			V																																			
T	2007	Envoy	Body	Disc Player and Video Display	V																				V																																			
T	2007	Envoy	Body	Driver Door Module	V	V																		V	V																																			
T	2007	Envoy	Body	Driver Seat Module	V	V																		V	V																																			
T	2007	Envoy	Body	Generator Battery Control Module	V	V																		V	V																																			
T	2007	Envoy	Body	HVAC Control Module Auto	V	V																		V	V																																			
T	2007	Envoy	Body	HVAC Control Module Manual	V	V																		V	V																																			
T	2007	Envoy	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2007	Envoy	Body	Lift Gate Module	V	V																		V	V																																			
T	2007	Envoy	Body	Passenger Door Module	V	V																		V	V																																			
T	2007	Envoy	Body	Passenger Presence System	V																																																						
T	2007	Envoy	Body	Uplevel Radio	V	V																			V																																			
T	2007	Envoy	Body	Navigation Radio	V	V																		V																																			
T	2007	Envoy	Body	Rear Seat Audio	V	V																			V																																			
T	2007	Envoy	Body	Supplemental Inflatable Restraint	V	V																			V																																			
T	2007	Envoy	Body	Theft Deterrent Module	V	V																																																					
T	2007	Envoy	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																					V													
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																								
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module	V																			V																																				
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																					V													
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module	V																			V																																				
T	2008	Canyon	Chassis	Electronic Brake Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2008	Canyon	Body	Body Control Module	V	V																		V	V																																				
T	2008	Canyon	Body	Digital Radio Receiver	V	V																			V																																				
T	2008	Canyon	Body	Generator Battery Control Module	V	V																		V	V																																				
T	2008	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																				
T	2008	Canyon	Body	Passenger Presence System	V																																																							
T	2008	Canyon	Body	Base Radio	V	V																			V																																			
T	2008	Canyon	Body	Uplevel Radio	V	V																			V																																			
T	2008	Canyon	Body	Supplemental Inflatable Restraint	V	V																																																						
T	2008	Canyon	Body	Theft Deterrent Module	V	V																																																						
T	2008	Canyon	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V																					V															
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																	V											V	V																									
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module	V	V																	V																																					
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V																					V															
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																	V											V	V																									
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																	V																																					
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V							V													V															
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																	V											V	V																									
T	2008	Envoy	Chassis	Electronic Brake Control Module	V	V																	V	V																																				
T	2008	Envoy	Body	Body Control Module	V	V																	V	V																																				
T	2008	Envoy	Body	Digital Radio Receiver	V	V																			V																																				
T	2008	Envoy	Body	Disc Player and Video Display	V																				V																																				
T	2008	Envoy	Body	Driver Door Module	V	V																	V	V																																				
T	2008	Envoy	Body	Driver Seat Module	V	V																	V	V																																				
T	2008	Envoy	Body	Generator Battery Control Module	V	V																	V	V																																				
T	2008	Envoy	Body	HVAC Control Module Auto	V	V																	V	V																																				
T	2008	Envoy	Body	HVAC Control Module Manual	V	V																	V	V																																				
T	2008	Envoy	Body	Instrument Panel Cluster	V	V																	V	V																																				
T	2008	Envoy	Body	Lift Gate Module	V	V																	V	V																																				
T	2008	Envoy	Body	Passenger Door Module	V	V																	V	V																																				
T	2008	Envoy	Body	Passenger Presence System	V																																																							
T	2008	Envoy	Body	Uplevel Radio	V	V																			V																																				
T	2008	Envoy	Body	Navigation Radio	V	V																	V																																					
T	2008	Envoy	Body	Rear Seat Audio	V	V																			V																																				
T	2008	Envoy	Body	Supplemental Inflatable Restraint	V	V																			V																																				
T	2008	Envoy	Body	Theft Deterrent Module	V	V																																																						
T	2008	Envoy	Body	Vehicle Comm. Interface Module	V	V																	V	V																																				
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V			V			V	V	V	V		V	V		V	V																					V															
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																	V											V	V																									
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																	V	V																																				
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module	V																		V																																					
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V			V			V	V	V	V		V	V		V	V																					V															
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																	V											V	V																									
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																	V	V																																				
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module	V																		V																																					
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module	V	V	V					V			V	V	V	V		V	V		V	V							V													V															
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module	V	V																	V											V	V																									
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module	V	V																	V	V																																				
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module	V																		V																																					
T	2009	Canyon	Chassis	Electronic Brake Control Module	V	V																	V	V																																				
T	2009	Canyon	Body	Body Control Module	V	V																	V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2009	Canyon	Body	Digital Radio Receiver	V	V																		V	V																																			
T	2009	Canyon	Body	Generator Battery Control Module	V	V																		V	V																																			
T	2009	Canyon	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2009	Canyon	Body	Passenger Presence System	V																																																						
T	2009	Canyon	Body	Base Radio	V	V																			V																																			
T	2009	Canyon	Body	Uplevel Radio	V	V																			V																																			
T	2009	Canyon	Body	Supplemental Inflatable Restraint	V	V																																																					
T	2009	Canyon	Body	Theft Deterrent Module	V	V																																																					
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module	V	V																		V										V	V																								
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module	V	V																		V																																			
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module	V	V																		V										V	V																								
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module	V	V																		V																																			
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V																				V														
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module	V	V																		V										V	V																								
T	2009	Envoy	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
T	2009	Envoy	Body	Body Control Module	V	V																		V	V																																			
T	2009	Envoy	Body	Digital Radio Receiver	V	V																		V	V																																			
T	2009	Envoy	Body	Disc Player and Video Display	V																				V																																			
T	2009	Envoy	Body	Driver Door Module	V	V																		V	V																																			
T	2009	Envoy	Body	Driver Seat Module	V	V																		V	V																																			
T	2009	Envoy	Body	Generator Battery Control Module	V	V																		V	V																																			
T	2009	Envoy	Body	HVAC Control Module Auto	V	V																		V	V																																			
T	2009	Envoy	Body	HVAC Control Module Manual	V	V																		V	V																																			
T	2009	Envoy	Body	Instrument Panel Cluster	V	V																		V	V																																			
T	2009	Envoy	Body	Lift Gate Module	V	V																		V	V																																			
T	2009	Envoy	Body	Passenger Door Module	V	V																		V	V																																			
T	2009	Envoy	Body	Passenger Presence System	V																																																						
T	2009	Envoy	Body	Uplevel Radio	V	V																			V																																			
T	2009	Envoy	Body	Navigation Radio	V	V																		V																																			
T	2009	Envoy	Body	Rear Seat Audio	V	V																			V																																			
T	2009	Envoy	Body	Supplemental Inflatable Restraint	V	V																			V																																			
T	2009	Envoy	Body	Theft Deterrent Module	V	V																																																					
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																								
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																			
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module	V																			V																																			
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																			
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module	V																			V																																			
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module	V	V																		V										V	V																								
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																			
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module	V																			V																																			
T	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
T	2010	ALL	Body	Body Control Module	V	V																		V	V																																			
T	2010	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
T	2010	ALL	Body	Generator Battery Control Module	V	V																		V	V																																			
T	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
T	2010	ALL	Body	Passenger Presence System	V																																																							
T	2010	ALL	Body	Personal Audio Link Module	V																				V																																			
T	2010	ALL	Body	Base Radio	V	V																			V																																			
T	2010	ALL	Body	Uplevel Radio	V	V																			V																																			
T	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
T	2010	ALL	Body	Theft Deterrent Module	V	V																																																						
T	2010	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
V	2007	ALL	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V															V	V	V	V		V													
V	2007	ALL	Powertrain	Rear Drive System	V	V																			V																																			
V	2007	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
V	2007	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
V	2007	ALL	Body	Body Control Module	V	V																		V	V																																			
V	2007	ALL	Body	Digital Radio Receiver	V	V																			V																																			
V	2007	ALL	Body	Driver Door Switch	V	V																		V	V																																			
V	2007	ALL	Body	Head Up Display	V	V																			V																																			
V	2007	ALL	Body	Heated Seat Module	V	V																			V																																			
V	2007	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
V	2007	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
V	2007	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
V	2007	ALL	Body	Lift Gate Module	V	V																		V	V																																			
V	2007	ALL	Body	Park Assist Module	V	V																		V	V																																			
V	2007	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
V	2007	ALL	Body	Passenger Presence System	V	V																			V																																			
V	2007	ALL	Body	Radio	V	V																		V	V																																			
V	2007	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
V	2007	ALL	Body	Rollover Sensor	V	V																			V																																			
V	2007	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
V	2007	ALL	Body	Theft Deterrent Module	V	V																			V																																			
V	2008	ALL	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V															V	V	V	V		V													
V	2008	ALL	Powertrain	Rear Drive System	V	V																			V																																			
V	2008	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
V	2008	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
V	2008	ALL	Body	Body Control Module	V	V																		V	V																																			
V	2008	ALL	Body	Digital Radio Receiver	V	V																			V																																			
V	2008	ALL	Body	Driver Door Switch	V	V																		V	V																																			
V	2008	ALL	Body	Head Up Display	V	V																			V																																			
V	2008	ALL	Body	Heated Seat Module	V	V																			V																																			
V	2008	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
V	2008	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
V	2008	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
V	2008	ALL	Body	Lift Gate Module	V	V																		V	V																																			
V	2008	ALL	Body	Park Assist Module	V	V																		V	V																																			
V	2008	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
V	2008	ALL	Body	Passenger Presence System	V	V																			V																																			
V	2008	ALL	Body	Radio	V	V																		V	V																																			
V	2008	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
V	2008	ALL	Body	Rollover Sensor	V	V																			V																																			
V	2008	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
V	2008	ALL	Body	Theft Deterrent Module	V	V																			V																																			
V	2009	ALL	Powertrain	Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V															V	V	V	V															
V	2009	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
V	2009	ALL	Powertrain	Rear Drive System	V	V																			V																																			
V	2009	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																						
V	2009	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
V	2009	ALL	Body	Body Control Module	V	V																		V	V																																		
V	2009	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
V	2009	ALL	Body	Driver Door Switch	V	V																		V	V																																		
V	2009	ALL	Body	Head Up Display	V	V																			V																																		
V	2009	ALL	Body	Heated Seat Module	V	V																			V																																		
V	2009	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																		
V	2009	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																		
V	2009	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
V	2009	ALL	Body	Lift Gate Module	V	V																		V	V																																		
V	2009	ALL	Body	Park Assist Module	V	V																		V	V																																		
V	2009	ALL	Body	Passenger Door Switch	V	V																		V	V																																		
V	2009	ALL	Body	Passenger Presence System	V	V																			V																																		
V	2009	ALL	Body	Radio	V	V																		V	V																																		
V	2009	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																		
V	2009	ALL	Body	Rollover Sensor	V	V																			V																																		
V	2009	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
V	2009	ALL	Body	Theft Deterrent Module	V	V																			V																																		
V	2010	ALL	Powertrain	Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V							V									V	V	V	V																
V	2010	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																		
V	2010	ALL	Powertrain	Rear Drive System	V	V																			V																																		
V	2010	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																						
V	2010	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
V	2010	ALL	Body	Body Control Module	V	V																		V	V																																		
V	2010	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
V	2010	ALL	Body	Driver Door Switch	V	V																		V	V																																		
V	2010	ALL	Body	Head Up Display	V	V																			V																																		
V	2010	ALL	Body	Heated Seat Module	V	V																			V																																		
V	2010	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																		
V	2010	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																		
V	2010	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
V	2010	ALL	Body	Lift Gate Module	V	V																		V	V																																		
V	2010	ALL	Body	Park Assist Module	V	V																			V																																		
V	2010	ALL	Body	Passenger Door Switch	V	V																		V	V																																		
V	2010	ALL	Body	Passenger Presence System	V	V																			V																																		
V	2010	ALL	Body	Radio	V	V																		V	V																																		
V	2010	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																		
V	2010	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
V	2010	ALL	Body	Theft Deterrent Module	V	V																			V																																		
V	2011	ALL	Powertrain	Engine Control Module	V	V	V		V				V		V	V	V	V	V		V	V		V	V						V									V	V	V	V																
V	2011	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																		
V	2011	ALL	Powertrain	Rear Drive System	V	V																			V																																		
V	2011	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																						
V	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
V	2011	ALL	Body	Body Control Module	V	V																		V	V																																		
V	2011	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
V	2011	ALL	Body	Driver Door Switch	V	V																		V	V																																		
V	2011	ALL	Body	Head Up Display	V	V																			V																																		
V	2011	ALL	Body	Heated Seat Module	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
V	2011	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
V	2011	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
V	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
V	2011	ALL	Body	Lift Gate Module	V	V																		V	V																																			
V	2011	ALL	Body	Park Assist Module	V	V																			V																																			
V	2011	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
V	2011	ALL	Body	Passenger Presence System	V	V																			V																																			
V	2011	ALL	Body	Radio	V	V																		V	V																																			
V	2011	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
V	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
V	2011	ALL	Body	Theft Deterrent Module	V	V																			V																																			
V	2012	ALL	Powertrain	Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V														
V	2012	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
V	2012	ALL	Powertrain	Rear Drive System	V	V																			V																																			
V	2012	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
V	2012	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		V	
V	2012	ALL	Body	Body Control Module	V	V																		V	V																																			
V	2012	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
V	2012	ALL	Body	Driver Door Switch	V	V																		V	V																																			
V	2012	ALL	Body	Head Up Display	V	V																			V																																			
V	2012	ALL	Body	Heated Seat Module	V	V																			V																																			
V	2012	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
V	2012	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
V	2012	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
V	2012	ALL	Body	Lift Gate Module	V	V																		V	V																																			
V	2012	ALL	Body	Park Assist Module	V	V																			V																																			
V	2012	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
V	2012	ALL	Body	Passenger Presence System	V	V																			V																																			
V	2012	ALL	Body	Radio	V	V																		V	V																																			
V	2012	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																			
V	2012	ALL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
V	2012	ALL	Body	Theft Deterrent Module	V	V																			V																																			
V	2013	ALL	Powertrain	Engine Control Module	V	V	V						V		V	V	V	V	V		V	V		V	V							V								V	V	V	V		V														
V	2013	ALL	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
V	2013	ALL	Powertrain	Rear Drive System	V	V																			V																																			
V	2013	ALL	Powertrain	Transmission Control Module	V	V																		V											V	V	V																							
V	2013	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		V	
V	2013	ALL	Body	Body Control Module	V	V																		V	V																																			
V	2013	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
V	2013	ALL	Body	Driver Door Switch	V	V																		V	V																																			
V	2013	ALL	Body	Head Up Display	V	V																			V																																			
V	2013	ALL	Body	Heated Seat Module	V	V																			V																																			
V	2013	ALL	Body	HVAC Control Module Auto	V	V																		V	V																																			
V	2013	ALL	Body	HVAC Control Module Manual	V	V																		V	V																																			
V	2013	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
V	2013	ALL	Body	Left Side Object Detection Module	V																			V	V																																			
V	2013	ALL	Body	Lift Gate Module	V	V																		V	V																																			
V	2013	ALL	Body	Park Assist Module	V	V																			V																																			
V	2013	ALL	Body	Passenger Door Switch	V	V																		V	V																																			
V	2013	ALL	Body	Passenger Presence System	V	V																			V																																			
V	2013	ALL	Body	Radio	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
V	2013	ALL	Body	Rear HVAC/RSA	V	V																		V	V																																				
V	2013	ALL	Body	Right Side Object Detection Module	V																			V	V																																				
V	2013	ALL	Body	Supplemental Inflatable Restraint	V	V																		V	V																																				
V	2013	ALL	Body	Theft Deterrent Module	V	V																			V																																				
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V		V															
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V								V														
V	2014	Acadia	Powertrain	Chassis Control Module	V	V																		V	V							V		V																											
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																				
V	2014	Acadia	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																				
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																				
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																				
V	2014	Acadia	Body	Passenger Presence Module	V	V																			V																																				
V	2014	Acadia	Body	Instrument Cluster	V	V																		V	V																																				
V	2014	Acadia	Body	Head-Up Display Module	V	V																			V																																				
V	2014	Acadia	Body	Radio	V	V																		V	V																																				
V	2014	Acadia	Body	Rear Audio Control Module	V	V																			V																																				
V	2014	Acadia	Body	Digital Radio Receiver Control Module	V	V																		V	V																																				
V	2014	Acadia	Body	Personal Audio Link Control Module	V																				V																																				
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																				
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																				
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																				
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																				
V	2014	Acadia	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V													
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																				
V	2014	Acadia	Body	Liftgate Control Module	V	V																			V																						V													
V	2014	Acadia	Body	Seat Memory Control Module	V	V																		V	V																																				
V	2014	Acadia	Body	Front Seat Heating Control Module	V	V																			V																																				
V	2014	Acadia	Body	Right Side Object Detection Control Module	V																			V	V																																				
V	2014	Acadia	Body	Left Side Object Detection Control Module	V																			V	V																																				
V	2014	Acadia	Body	Remote Control Door Lock Receiver	V	V																		V	V																																				
V	2014	Acadia	Body	Parking Assist Control Module	V																			V	V																																				
V	2014	Acadia	Body	Frontview Camera Module	V	V																		V	V																																				
V	2014	Acadia	Body	Theft Deterrent Module	V	V																			V																																				
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V		V															
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V								V														
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																				
V	2015	Acadia	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																				
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																				
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																				
V	2015	Acadia	Body	Passenger Presence Module	V	V																			V																																				
V	2015	Acadia	Body	Instrument Cluster	V	V																		V	V																																				
V	2015	Acadia	Body	Head-Up Display Module	V	V																		V	V																																				
V	2015	Acadia	Body	Radio	V	V																		V	V																																				
V	2015	Acadia	Body	Rear Audio Control Module	V	V																			V																																				
V	2015	Acadia	Body	Digital Radio Receiver Control Module	V	V																		V	V																																				
V	2015	Acadia	Body	Personal Audio Link Control Module	V																				V																																				
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																				
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																				
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
V	2015	Acadia	Body	Driver Door Switch Panel Control Module	V	V																		V	V																					V												
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
V	2015	Acadia	Body	Liftgate Control Module	V	V																			V																					V												
V	2015	Acadia	Body	Seat Memory Control Module	V	V																		V	V																																		
V	2015	Acadia	Body	Front Seat Heating Control Module	V	V																			V																																		
V	2015	Acadia	Body	Right Side Object Detection Control Module	V																			V	V																																		
V	2015	Acadia	Body	Left Side Object Detection Control Module	V																			V	V																																		
V	2015	Acadia	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
V	2015	Acadia	Body	Parking Assist Control Module	V																			V	V																																		
V	2015	Acadia	Body	Frontview Camera Module	V	V																		V	V																																		
V	2015	Acadia	Body	Theft Deterrent Module	V	V																			V																																		
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V		V													
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module	V	V																		V	V										V	V	V	V									V											
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module	V	V																		V	V																																		
V	2016	Acadia	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						V
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate	V	V																		V	V																																		
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)	V	V																		V	V																																		
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
V	2016	Acadia	Body	Passenger Presence Module	V	V																			V																																		
V	2016	Acadia	Body	Instrument Cluster	V	V																		V	V																																		
V	2016	Acadia	Body	Head-Up Display Module	V	V																		V	V																																		
V	2016	Acadia	Body	Radio	V	V																		V	V																																		
V	2016	Acadia	Body	Rear Audio Control Module	V	V																			V																																		
V	2016	Acadia	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
V	2016	Acadia	Body	Personal Audio Link Control Module	V																				V																																		
V	2016	Acadia	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																		
V	2016	Acadia	Body	Driver Door Switch Panel Control Module	V	V																		V	V																					V												
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
V	2016	Acadia	Body	Liftgate Control Module	V	V																			V																					V												
V	2016	Acadia	Body	Seat Memory Control Module	V	V																		V	V																																		
V	2016	Acadia	Body	Front Seat Heating Control Module	V	V																			V																																		
V	2016	Acadia	Body	Right Side Object Detection Control Module	V																			V	V																																		
V	2016	Acadia	Body	Left Side Object Detection Control Module	V																			V	V																																		
V	2016	Acadia	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
V	2016	Acadia	Body	Parking Assist Control Module	V																			V	V																																		
V	2016	Acadia	Body	Frontview Camera Module	V	V																		V	V																																		
V	2016	Acadia	Body	Theft Deterrent Module	V	V																			V																																		
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V					V			V	V	V	V		V	V			V	V						V														V													
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																							
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V	V		V			V	V	V	V		V	V		V	V			V	V						V														V													
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																		
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																							
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V			V	V	V	V		V	V		V	V			V	V						V														V													
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																						
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V			V	V	V	V		V	V		V	V			V	V						V														V													
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V		V	V	V	V	V		V	V		V	V							V													V														
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V													
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																	
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																						
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																	
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																	
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module	V	V																		V	V																																	
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																						
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V								V						V			V	V																																	
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module		V													V					V	V																																	
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module	V	V																		V	V																																	
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module	V	V																		V										V	V	V																						
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES	V	V																		V	V																																	
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES	V	V																		V	V																																	
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																	
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																	
1	2011	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																	
1	2011	Sierra	Chassis	Trailer Brake Control Module	V	V																		V	V																																	
1	2011	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																	
1	2011	Sierra	Body	Body Control Module	V	V																		V	V																																	
1	2011	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																	
1	2011	Sierra	Body	Digital Radio Receiver	V	V																		V	V																																	
1	2011	Sierra	Body	Driver Door Switch	V	V																		V	V																																	
1	2011	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																	
1	2011	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																	
1	2011	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																	
1	2011	Sierra	Body	Memory Seat Module	V	V																		V	V																																	
1	2011	Sierra	Body	Park Assist Module	V	V																			V																																	
1	2011	Sierra	Body	Passenger Door Switch	V	V																		V	V																																	
1	2011	Sierra	Body	Passenger Presence System	V	V																			V																																	
1	2011	Sierra	Body	Radio	V	V																		V	V																																	
1	2011	Sierra	Body	Rear Heated Seat Module	V	V																			V																																	
1	2011	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																	
1	2011	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																	
1	2011	Sierra	Body	Theft Deterrent Module	V	V																			V																																	
1	2011	Sierra Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module	V	V																		V																																	
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module		V																		V																																	
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																	
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																	
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1		V																																																			
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2		V																																																			
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module	V	V																		V										V		V																						
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																	
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																	
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																	
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module	V	V																																																			
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module	V	V																			V																																	
1	2011	Sierra Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																	
1	2011	Sierra Hybrid	Body	Body Control Module	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																				
1	2011	Sierra Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
1	2011	Sierra Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
1	2011	Sierra Hybrid	Body	Heated Seat Module	V	V																			V																																			
1	2011	Sierra Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
1	2011	Sierra Hybrid	Body	Park Assist Module	V	V																			V																																			
1	2011	Sierra Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
1	2011	Sierra Hybrid	Body	Passenger Presence System	V	V																			V																																			
1	2011	Sierra Hybrid	Body	Radio	V	V																		V	V																																			
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
1	2011	Sierra Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																							
1	2011	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
1	2011	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																			
1	2011	Yukon	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
1	2011	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																			
1	2011	Yukon	Body	Assist Step Controller	V	V																		V	V																																			
1	2011	Yukon	Body	Body Control Module	V	V																		V	V																																			
1	2011	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																			
1	2011	Yukon	Body	Digital Radio Receiver	V	V																		V	V																																			
1	2011	Yukon	Body	Driver Door Switch	V	V																		V	V																																			
1	2011	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																			
1	2011	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																			
1	2011	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																			
1	2011	Yukon	Body	Left Side Object Detection Module	V	V																		V	V																																			
1	2011	Yukon	Body	Lift Gate Module	V	V																		V	V																																			
1	2011	Yukon	Body	Memory Seat Module	V	V																		V	V																																			
1	2011	Yukon	Body	Park Assist Module	V	V																			V																																			
1	2011	Yukon	Body	Passenger Door Switch	V	V																		V	V																																			
1	2011	Yukon	Body	Passenger Presence System	V	V																			V																																			
1	2011	Yukon	Body	Radio	V	V																		V	V																																			
1	2011	Yukon	Body	Rear Heated Seat Module	V	V																			V																																			
1	2011	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																			
1	2011	Yukon	Body	Right Side Object Detection Module	V	V																			V																																			
1	2011	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																			
1	2011	Yukon	Body	Theft Deterrent Module	V	V																			V																																			
1	2011	Yukon Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V													
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module	V	V																		V																																			
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module		V																		V																																			
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1		V																																																								
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2		V																																																								
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module	V	V																	V										V		V																										
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module	V	V																	V	V																																				
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control	V	V																	V	V																																				
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																	V	V																																				
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module	V	V																																																						
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module	V	V																		V																																				
1	2011	Yukon Hybrid	Body	Amplifier (Bose)	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Assist Step Controller	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Body Control Module	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Digital Radio Receiver	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Driver Door Switch	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Heated Seat Module	V	V																		V																																				
1	2011	Yukon Hybrid	Body	HVAC Control Module	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Lift Gate Module	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Park Assist Module	V	V																		V																																				
1	2011	Yukon Hybrid	Body	Passenger Door Switch	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Passenger Presence System	V	V																		V																																				
1	2011	Yukon Hybrid	Body	Radio	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module	V	V																		V																																				
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module	V	V																		V																																				
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module	V	V																	V	V																																				
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint	V	V																		V																																				
1	2011	Yukon Hybrid	Body	Theft Deterrent Module	V	V																		V																																				
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V														
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																								
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V														
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V														V														
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																								
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V														
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																								
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																			
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
1	2011	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
1	2011	Yukon XL	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
1	2011	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																			
1	2011	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																			
1	2011	Yukon XL	Body	Body Control Module	V	V																		V	V																																			
1	2011	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																			
1	2011	Yukon XL	Body	Digital Radio Receiver	V	V																		V	V																																			
1	2011	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2011	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																			
1	2011	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																			
1	2011	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																			
1	2011	Yukon XL	Body	Left Side Object Detection Module	V	V																		V	V																																			
1	2011	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																			
1	2011	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																			
1	2011	Yukon XL	Body	Park Assist Module	V	V																			V																																			
1	2011	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																			
1	2011	Yukon XL	Body	Passenger Presence System	V	V																			V																																			
1	2011	Yukon XL	Body	Radio	V	V																		V	V																																			
1	2011	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																			
1	2011	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																			
1	2011	Yukon XL	Body	Right Side Object Detection Module	V	V																			V																																			
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
1	2011	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																			
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V		V	V			V	V						V														V														
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																								
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																			
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																								
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V		V	V	V	V	V		V	V		V	V						V														V														
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																			
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																			
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module	V	V																		V	V																																			
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																							
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V								V						V			V	V																																			
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module		V													V					V	V																																			
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module	V	V																		V	V																																			
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module	V	V																		V										V	V	V																							
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES	V	V																		V	V																																			
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES	V	V																		V	V																																			
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																			
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																			
1	2012	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																			
1	2012	Sierra	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
1	2012	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																			
1	2012	Sierra	Body	Body Control Module	V	V																		V	V																																			
1	2012	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																			
1	2012	Sierra	Body	Digital Radio Receiver	V	V																		V	V																																			
1	2012	Sierra	Body	Driver Door Switch	V	V																		V	V																																			
1	2012	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2012	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																			
1	2012	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																			
1	2012	Sierra	Body	Memory Seat Module	V	V																		V	V																																			
1	2012	Sierra	Body	Park Assist Module	V	V																			V																																			
1	2012	Sierra	Body	Passenger Door Switch	V	V																		V	V																																			
1	2012	Sierra	Body	Passenger Presence System	V	V																			V																																			
1	2012	Sierra	Body	Radio	V	V																		V	V																																			
1	2012	Sierra	Body	Navigation Radio	V	V																		V	V																																			
1	2012	Sierra	Body	Rear Heated Seat Module	V	V																			V																																			
1	2012	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																			
1	2012	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																			
1	2012	Sierra	Body	Theft Deterrent Module	V	V																			V																																			
1	2012	Sierra Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V													
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module	V	V																		V																																			
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module		V																		V																																			
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																			
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1		V																																																					
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2		V																																																					
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module	V	V																		V											V		V																							
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module	V	V																																																					
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
1	2012	Sierra Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
1	2012	Sierra Hybrid	Body	Body Control Module	V	V																		V	V																																			
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
1	2012	Sierra Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
1	2012	Sierra Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
1	2012	Sierra Hybrid	Body	Heated Seat Module	V	V																			V																																			
1	2012	Sierra Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
1	2012	Sierra Hybrid	Body	Park Assist Module	V	V																			V																																			
1	2012	Sierra Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
1	2012	Sierra Hybrid	Body	Passenger Presence System	V	V																			V																																			
1	2012	Sierra Hybrid	Body	Radio	V	V																		V	V																																			
1	2012	Sierra Hybrid	Body	Navigation Radio	V	V																		V	V																																			
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
1	2012	Sierra Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																							
1	2012	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
1	2012	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2012	Yukon	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
1	2012	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																			
1	2012	Yukon	Body	Assist Step Controller	V	V																		V	V																																			
1	2012	Yukon	Body	Body Control Module	V	V																		V	V																																			
1	2012	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																			
1	2012	Yukon	Body	Digital Radio Receiver	V	V																		V	V																																			
1	2012	Yukon	Body	Driver Door Switch	V	V																		V	V																																			
1	2012	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																			
1	2012	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																			
1	2012	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																			
1	2012	Yukon	Body	Left Side Object Detection Module	V	V																		V	V																																			
1	2012	Yukon	Body	Lift Gate Module	V	V																		V	V																																			
1	2012	Yukon	Body	Memory Seat Module	V	V																		V	V																																			
1	2012	Yukon	Body	Park Assist Module	V	V																			V																																			
1	2012	Yukon	Body	Passenger Door Switch	V	V																		V	V																																			
1	2012	Yukon	Body	Passenger Presence System	V	V																			V																																			
1	2012	Yukon	Body	Radio	V	V																		V	V																																			
1	2012	Yukon	Body	Navigation Radio	V	V																		V	V																																			
1	2012	Yukon	Body	Rear Heated Seat Module	V	V																			V																																			
1	2012	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																			
1	2012	Yukon	Body	Right Side Object Detection Module	V	V																			V																																			
1	2012	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																			
1	2012	Yukon	Body	Theft Deterrent Module	V	V																			V																																			
1	2012	Yukon Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V														
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module	V	V																		V																																			
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module		V																		V																																			
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																			
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1		V																																																				
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2		V																																																				
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module	V	V																		V										V		V																							
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module	V	V																																																				
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
1	2012	Yukon Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Assist Step Controller	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Body Control Module	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Heated Seat Module	V	V																			V																																			
1	2012	Yukon Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Lift Gate Module	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Park Assist Module	V	V																			V																																			
1	2012	Yukon Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Passenger Presence System	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2012	Yukon Hybrid	Body	Radio	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Navigation Radio	V	V																		V	V																																			
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module	V	V																			V																																		
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																		
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module	V	V																			V																																		
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																		
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																		
1	2012	Yukon Hybrid	Body	Theft Deterrent Module	V	V																			V																																		
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																	
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																						
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																	
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																						
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																	
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																						
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																		
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																		
1	2012	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																		
1	2012	Yukon XL	Chassis	Trailer Brake Control Module	V	V																		V	V																																		
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
1	2012	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																		
1	2012	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																		
1	2012	Yukon XL	Body	Body Control Module	V	V																		V	V																																		
1	2012	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																		
1	2012	Yukon XL	Body	Digital Radio Receiver	V	V																		V	V																																		
1	2012	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																		
1	2012	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																		
1	2012	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																		
1	2012	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																		
1	2012	Yukon XL	Body	Left Side Object Detection Module	V	V																		V	V																																		
1	2012	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																		
1	2012	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																		
1	2012	Yukon XL	Body	Park Assist Module	V	V																			V																																		
1	2012	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																		
1	2012	Yukon XL	Body	Passenger Presence System	V	V																			V																																		
1	2012	Yukon XL	Body	Radio	V	V																		V	V																																		
1	2012	Yukon XL	Body	Navigation Radio	V	V																		V	V																																		
1	2012	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																		
1	2012	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																		
1	2012	Yukon XL	Body	Right Side Object Detection Module	V	V																			V																																		
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
1	2012	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																		
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																						
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																	
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V		V	V	V	V	V		V	V		V	V							V													V														
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V			V				V		V	V	V	V	V		V	V		V	V							V													V														
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module	V																				V																																		
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																							
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																		
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V								V						V			V	V																																		
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module		V													V					V	V																																		
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module	V	V																		V	V																																		
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module	V	V																		V										V	V	V																							
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES	V	V																		V	V																																		
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																		
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
1	2013	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																		
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
1	2013	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																		
1	2013	Sierra	Body	Body Control Module	V	V																		V	V																																		
1	2013	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																		
1	2013	Sierra	Body	Digital Radio Receiver	V	V																		V	V																																		
1	2013	Sierra	Body	Driver Door Switch	V	V																		V	V																																		
1	2013	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																		
1	2013	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																		
1	2013	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																		
1	2013	Sierra	Body	Memory Seat Module	V	V																		V	V																																		
1	2013	Sierra	Body	Park Assist Module	V	V																			V																																		
1	2013	Sierra	Body	Passenger Door Switch	V	V																		V	V																																		
1	2013	Sierra	Body	Passenger Presence System	V	V																			V																																		
1	2013	Sierra	Body	Radio	V	V																		V	V																																		
1	2013	Sierra	Body	Navigation Radio	V	V																		V	V																																		
1	2013	Sierra	Body	Rear Heated Seat Module	V	V																			V																																		
1	2013	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																		
1	2013	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																		
1	2013	Sierra	Body	Theft Deterrent Module	V	V																			V																																		
1	2013	Sierra Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V														
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module	V	V																		V																																		
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module		V																		V																																		
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																		
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																		
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1		V																																																			
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2		V																																																			
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module	V	V																		V										V		V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module	V	V																																																					
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		
1	2013	Sierra Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																		
1	2013	Sierra Hybrid	Body	Body Control Module	V	V																		V	V																																		
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																		
1	2013	Sierra Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																		
1	2013	Sierra Hybrid	Body	Driver Door Switch	V	V																		V	V																																		
1	2013	Sierra Hybrid	Body	Heated Seat Module	V	V																			V																																		
1	2013	Sierra Hybrid	Body	HVAC Control Module	V	V																		V	V																																		
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																		
1	2013	Sierra Hybrid	Body	Park Assist Module	V	V																			V																																		
1	2013	Sierra Hybrid	Body	Passenger Door Switch	V	V																		V	V																																		
1	2013	Sierra Hybrid	Body	Passenger Presence System	V	V																			V																																		
1	2013	Sierra Hybrid	Body	Radio	V	V																		V	V																																		
1	2013	Sierra Hybrid	Body	Navigation Radio	V	V																		V	V																																		
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module	V	V																			V																																		
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																		
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																		
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																		
1	2013	Sierra Hybrid	Body	Theft Deterrent Module	V	V																			V																																		
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																						
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																		
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																						
1	2013	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
1	2013	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																		
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
1	2013	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																		
1	2013	Yukon	Body	Assist Step Controller	V	V																		V	V																																		
1	2013	Yukon	Body	Body Control Module	V	V																		V	V																																		
1	2013	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																		
1	2013	Yukon	Body	Digital Radio Receiver	V	V																		V	V																																		
1	2013	Yukon	Body	Driver Door Switch	V	V																		V	V																																		
1	2013	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																		
1	2013	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																		
1	2013	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																		
1	2013	Yukon	Body	Left Side Object Detection Module	V	V																		V	V																																		
1	2013	Yukon	Body	Lift Gate Module	V	V																		V	V																																		
1	2013	Yukon	Body	Memory Seat Module	V	V																		V	V																																		
1	2013	Yukon	Body	Park Assist Module	V	V																			V																																		
1	2013	Yukon	Body	Passenger Door Switch	V	V																		V	V																																		
1	2013	Yukon	Body	Passenger Presence System	V	V																			V																																		
1	2013	Yukon	Body	Radio	V	V																		V	V																																		
1	2013	Yukon	Body	Navigation Radio	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2013	Yukon	Body	Rear Heated Seat Module	V	V																			V																																			
1	2013	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																			
1	2013	Yukon	Body	Right Side Object Detection Module	V	V																			V																																			
1	2013	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																			
1	2013	Yukon	Body	Theft Deterrent Module	V	V																			V																																			
1	2013	Yukon Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V													
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module	V	V																		V																																			
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module		V																		V																																			
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																			
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1		V																																																					
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2		V																																																					
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module	V	V																		V										V		V																							
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module	V	V																																																				
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		
1	2013	Yukon Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Assist Step Controller	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Body Control Module	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Driver Door Switch	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Heated Seat Module	V	V																			V																																		
1	2013	Yukon Hybrid	Body	HVAC Control Module	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Lift Gate Module	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Park Assist Module	V	V																			V																																		
1	2013	Yukon Hybrid	Body	Passenger Door Switch	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Passenger Presence System	V	V																			V																																		
1	2013	Yukon Hybrid	Body	Radio	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Navigation Radio	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module	V	V																			V																																		
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module	V	V																			V																																		
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																		
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																		
1	2013	Yukon Hybrid	Body	Theft Deterrent Module	V	V																			V																																		
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																						
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																						
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																								
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																			
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
1	2013	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
1	2013	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																			
1	2013	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																			
1	2013	Yukon XL	Body	Body Control Module	V	V																		V	V																																			
1	2013	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																			
1	2013	Yukon XL	Body	Digital Radio Receiver	V	V																		V	V																																			
1	2013	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																			
1	2013	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																			
1	2013	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																			
1	2013	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																			
1	2013	Yukon XL	Body	Left Side Object Detection Module	V	V																		V	V																																			
1	2013	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																			
1	2013	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																			
1	2013	Yukon XL	Body	Park Assist Module	V	V																			V																																			
1	2013	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																			
1	2013	Yukon XL	Body	Passenger Presence System	V	V																			V																																			
1	2013	Yukon XL	Body	Radio	V	V																		V	V																																			
1	2013	Yukon XL	Body	Navigation Radio	V	V																		V	V																																			
1	2013	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																			
1	2013	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																			
1	2013	Yukon XL	Body	Right Side Object Detection Module	V	V																			V																																			
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
1	2013	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																			
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V				V	V	V	V	V													V														
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V				V	V	V	V	V													V														
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V									V	V	V	V											V												
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V														
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V											V												
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V														
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V									V	V	V	V											V												
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																			
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																			
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
1	2014	Sierra	Chassis	Electronic Brake Control Module	V	V																		V	V												V													V	V	V	V	V	V						
1	2014	Sierra	Chassis	Parking Brake Control Module	V	V																			V																															V	V	V	V			
1	2014	Sierra	Chassis	Power Steering Control Module	V	V																		V	V																																			
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
1	2014	Sierra	Body	Body Control Module	V	V																		V	V																																			
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
1	2014	Sierra	Body	Passenger Presence Module	V	V																			V																																			
1	2014	Sierra	Body	Instrument Cluster	V	V																		V	V																																			
1	2014	Sierra	Body	Radio Control	V																				V																																			
1	2014	Sierra	Body	HVAC Control	V																			V	V																																			
1	2014	Sierra	Body	Radio	V	V																		V	V																																			
1	2014	Sierra	Body	Amplifier	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2014	Sierra	Body	Media Disc Player	V	V																		V	V																																			
1	2014	Sierra	Body	Human Machine Interface Control Module	V	V																		V	V																					V												
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																	
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																	
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																	
1	2014	Sierra	Body	Parking Assist Control Module	V																			V	V																																	
1	2014	Sierra	Body	Frontview Camera Module	V	V																		V	V																																	
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V												V												
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V												
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V												V												
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module	V	V																		V																																	
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V									V												
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module	V																			V	V						V		V																								
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module		V								V					V					V	V																																	
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																	
1	2014	Sierra HD	Powertrain	Transfer Case Control Module	V	V																		V	V																																	
1	2014	Sierra HD	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
1	2014	Sierra HD	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V		
1	2014	Sierra HD	Chassis	Trailer Brake Control Module	V	V																		V	V																																	
1	2014	Sierra HD	Chassis	Suspension Control Module	V	V																		V	V																																	
1	2014	Sierra HD	Body	Body Control Module	V	V																		V	V																																	
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
1	2014	Sierra HD	Body	Instrument Cluster	V	V																		V	V																																	
1	2014	Sierra HD	Body	Base Radio	V	V																		V	V																																	
1	2014	Sierra HD	Body	Navigation Radio	V	V																		V	V																																	
1	2014	Sierra HD	Body	Uplevel Radio	V	V																		V	V																																	
1	2014	Sierra HD	Body	Amplifier	V	V																			V																																	
1	2014	Sierra HD	Body	Rear Audio Control Module	V	V																			V																																	
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module	V	V																		V	V																																	
1	2014	Sierra HD	Body	Personal Audio Link Control Module	V																				V																																	
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																	
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																	
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)	V	V																		V	V																																	
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																	
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module	V	V																		V	V																					V												
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																	
1	2014	Sierra HD	Body	Seat Memory Control Module	V	V																		V	V																																	
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
1	2014	Sierra HD	Body	Parking Assist Control Module	V	V																		V	V																																	
1	2014	Sierra HD	Body	Theft Deterrent Module	V	V																			V																																	
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module	V																			V	V	V			V	V	V	V	V												V												
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module	V	V																		V	V									V	V	V	V									V												
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module	V																			V	V	V			V	V	V	V	V												V												
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module	V	V																		V	V									V	V	V	V									V												
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V																									
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control	V	V									V									V	V							V																									
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
1	2014	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
1	2014	Yukon	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
1	2014	Yukon	Chassis	Suspension Control Module	V	V																		V	V																																		
1	2014	Yukon	Body	Body Control Module	V	V																		V	V																																		
1	2014	Yukon	Body	Auxiliary Body Control Module	V	V																		V	V																																		
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
1	2014	Yukon	Body	Passenger Presence Module	V	V																			V																																		
1	2014	Yukon	Body	Instrument Cluster	V	V																		V	V																																		
1	2014	Yukon	Body	Base Radio	V	V																		V	V																																		
1	2014	Yukon	Body	Navigation Radio	V	V																		V	V																																		
1	2014	Yukon	Body	Uplevel Radio	V	V																		V	V																																		
1	2014	Yukon	Body	Amplifier	V	V																			V																																		
1	2014	Yukon	Body	Rear Audio Control Module	V	V																			V																																		
1	2014	Yukon	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
1	2014	Yukon	Body	Personal Audio Link Control Module	V																				V																																		
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)	V	V																		V	V																																		
1	2014	Yukon	Body	Driver Door Switch Panel Control Module	V	V																		V	V																						V											
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
1	2014	Yukon	Body	Liftgate Control Module	V	V																			V																						V											
1	2014	Yukon	Body	Seat Memory Control Module	V	V																		V	V																																		
1	2014	Yukon	Body	Rear Seat Heating Control Module	V	V																		V	V																																		
1	2014	Yukon	Body	Assist Step Control Module	V	V																		V	V																																		
1	2014	Yukon	Body	Right Side Object Detection Control Module	V	V																		V	V																																		
1	2014	Yukon	Body	Left Side Object Detection Control Module	V	V																		V	V																																		
1	2014	Yukon	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
1	2014	Yukon	Body	Parking Assist Control Module	V	V																		V	V																																		
1	2014	Yukon	Body	Theft Deterrent Module	V	V																			V																																		
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module	V	V																		V	V										V	V	V	V									V											
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module	V																			V	V	V			V	V	V	V	V													V											
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module	V	V																		V	V										V	V	V	V									V											
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module	V																			V	V	V			V	V	V	V	V													V											
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module	V	V																		V	V										V	V	V	V									V											
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V																										
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control	V	V									V									V	V							V																										
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
1	2014	Yukon XL	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
1	2014	Yukon XL	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
1	2014	Yukon XL	Chassis	Suspension Control Module	V	V																		V	V																																		
1	2014	Yukon XL	Body	Body Control Module	V	V																		V	V																																		
1	2014	Yukon XL	Body	Auxiliary Body Control Module	V	V																		V	V																																		
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
1	2014	Yukon XL	Body	Passenger Presence Module	V	V																			V																																		
1	2014	Yukon XL	Body	Instrument Cluster	V	V																		V	V																																		
1	2014	Yukon XL	Body	Base Radio	V	V																		V	V																																		
1	2014	Yukon XL	Body	Navigation Radio	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2014	Yukon XL	Body	Uplevel Radio	V	V																		V	V																																			
1	2014	Yukon XL	Body	Amplifier	V	V																			V																																			
1	2014	Yukon XL	Body	Rear Audio Control Module	V	V																			V																																			
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module	V	V																		V	V																																			
1	2014	Yukon XL	Body	Personal Audio Link Control Module	V																				V																																			
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)	V	V																		V	V																																			
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module	V	V																		V	V																								V											
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																			
1	2014	Yukon XL	Body	Liftgate Control Module	V	V																			V																								V											
1	2014	Yukon XL	Body	Seat Memory Control Module	V	V																		V	V																																			
1	2014	Yukon XL	Body	Rear Seat Heating Control Module	V	V																		V	V																																			
1	2014	Yukon XL	Body	Assist Step Control Module	V	V																		V	V																																			
1	2014	Yukon XL	Body	Right Side Object Detection Control Module	V	V																		V	V																																			
1	2014	Yukon XL	Body	Left Side Object Detection Control Module	V	V																		V	V																																			
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																			
1	2014	Yukon XL	Body	Parking Assist Control Module	V	V																		V	V																																			
1	2014	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																			
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V			V	V	V	V	V													V														
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V			V	V	V	V	V													V														
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V									V	V	V	V										V												
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V			V	V	V	V	V													V														
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V										V												
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V			V	V	V	V	V													V														
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V										V												
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V			V	V	V	V	V													V														
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module	V	V																		V																																			
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V										V												
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V			V	V	V	V	V													V														
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V										V												
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																			
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module	V																			V	V						V		V																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module		V								V					V					V	V																																			
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)	V	V																		V	V									V	V	V	V		V																			
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)	V	V																		V	V									V	V	V	V		V																			
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																			
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																			
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																			
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																			
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																			
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)	V	V																		V	V																																			
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
1	2015	Sierra	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
1	2015	Sierra	Chassis	Power Steering Control Module	V	V																		V	V																																			
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
1	2015	Sierra	Chassis	Suspension Control Module	V	V																		V	V																																			
1	2015	Sierra	Body	Body Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
1	2015	Sierra	Body	Passenger Presence Module	V	V																			V																																			
1	2015	Sierra	Body	Instrument Cluster	V	V																		V	V																																			
1	2015	Sierra	Body	Radio Controls	V																				V																																			
1	2015	Sierra	Body	HVAC Controls	V																			V	V																																			
1	2015	Sierra	Body	Radio	V	V																		V	V																																			
1	2015	Sierra	Body	Amplifier	V	V																			V																																			
1	2015	Sierra	Body	Media Disc Player	V	V																		V	V																																			
1	2015	Sierra	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																			
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																			
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
1	2015	Sierra	Body	Parking Assist Control Module	V																			V	V																																			
1	2015	Sierra	Body	Frontview Camera Module	V	V																		V	V																																			
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V													
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V										V												
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V													
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V										V												
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V								V												
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																			
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																			
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control	V	V																		V	V																																			
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																			
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
1	2015	Yukon	Powertrain	Drive Motor Control Module 1		V																			V																																			
1	2015	Yukon	Powertrain	Drive Motor Control Module 2		V																			V																																			
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																			
1	2015	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
1	2015	Yukon	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																			
1	2015	Yukon	Chassis	Power Steering Control Module	V	V																		V	V																																			
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
1	2015	Yukon	Chassis	Suspension Control Module	V	V																		V	V																																			
1	2015	Yukon	Body	Body Control Module	V	V																		V	V																																			
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
1	2015	Yukon	Body	Passenger Presence Module	V	V																			V																																			
1	2015	Yukon	Body	Instrument Cluster	V	V																		V	V																																			
1	2015	Yukon	Body	Radio Controls	V																				V																																			
1	2015	Yukon	Body	HVAC Controls	V																			V	V																																			
1	2015	Yukon	Body	Radio	V	V																		V	V																																			
1	2015	Yukon	Body	Amplifier	V	V																			V																																			
1	2015	Yukon	Body	Media Disc Player	V	V																		V	V																																			
1	2015	Yukon	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																			
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																			
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2015	Yukon	Body	HVAC Control Module	V	V																		V	V																																			
1	2015	Yukon	Body	Liftgate Control Module	V	V																			V																					V												
1	2015	Yukon	Body	Keyless Entry Control Module	V	V																		V	V																																		
1	2015	Yukon	Body	Assist Step Control Module	V	V																		V	V																																		
1	2015	Yukon	Body	Left Side Object Detection Control Module	V																			V	V																																		
1	2015	Yukon	Body	Parking Assist Control Module	V																			V	V																																		
1	2015	Yukon	Body	Frontview Camera Module	V	V																			V																																		
1	2015	Yukon	Body	Steering Column Lock Control Module	V	V																			V																																		
1	2015	Yukon	Body	Battery Energy Control Module		V																			V																																		
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V												V													
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V												
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V												
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V												
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																		
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																		
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																		
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control	V	V																		V	V																																		
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																		
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
1	2015	Yukon XL	Chassis	Electronic Brake Control Module	V	V																		V	V												V									V	V	V	V	V	V						
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
1	2015	Yukon XL	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		
1	2015	Yukon XL	Chassis	Power Steering Control Module	V	V																		V	V																																		
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
1	2015	Yukon XL	Chassis	Suspension Control Module	V	V																		V	V																																		
1	2015	Yukon XL	Body	Body Control Module	V	V																		V	V																																		
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
1	2015	Yukon XL	Body	Passenger Presence Module	V	V																			V																																		
1	2015	Yukon XL	Body	Instrument Cluster	V	V																		V	V																																		
1	2015	Yukon XL	Body	Radio Controls	V																				V																																		
1	2015	Yukon XL	Body	HVAC Controls	V																			V	V																																		
1	2015	Yukon XL	Body	Radio	V	V																		V	V																																		
1	2015	Yukon XL	Body	Amplifier	V	V																			V																																		
1	2015	Yukon XL	Body	Media Disc Player	V	V																		V	V																																		
1	2015	Yukon XL	Body	Human Machine Interface Control Module	V	V																		V	V																					V												
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																		
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
1	2015	Yukon XL	Body	HVAC Control Module	V	V																		V	V																																		
1	2015	Yukon XL	Body	Liftgate Control Module	V	V																			V																					V												
1	2015	Yukon XL	Body	Keyless Entry Control Module	V	V																		V	V																																		
1	2015	Yukon XL	Body	Assist Step Control Module	V	V																		V	V																																		
1	2015	Yukon XL	Body	Left Side Object Detection Control Module	V																			V	V																																		
1	2015	Yukon XL	Body	Parking Assist Control Module	V																			V	V																																		
1	2015	Yukon XL	Body	Frontview Camera Module	V	V																			V																																		
1	2015	Yukon XL	Body	Steering Column Lock Control Module	V	V																			V																																		
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V				V	V	V	V	V												V												
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V				V	V	V	V	V												V												
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V									V	V	V	V									V												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V												V															
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V													
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																			
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module	V																			V	V				V	V	V	V	V												V														
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module	V	V																		V	V									V	V	V	V		V																			
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module	V	V	V	V																V	V																																	
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2	V	V																		V	V																																	
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V												V														
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V												V														
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module	V	V																		V																																		
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V									V														
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V														
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V														
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																			
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module	V																			V	V						V		V																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module		V								V					V					V	V																																		
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module	V	V																		V	V									V	V	V	V		V																			
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																	
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																	
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)	V	V																		V	V																																	
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																	
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																	
1	2016	Sierra	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																	
1	2016	Sierra	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
1	2016	Sierra	Chassis	Power Steering Control Module	V	V																			V																																	
1	2016	Sierra	Chassis	Power Steering Control Module	V	V																		V	V																																	
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
1	2016	Sierra	Chassis	Suspension Control Module	V	V																		V	V																																	
1	2016	Sierra	Body	Body Control Module	V	V																		V	V																																	
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
1	2016	Sierra	Body	Passenger Presence Module	V	V																			V																																	
1	2016	Sierra	Body	Instrument Cluster	V	V																		V	V																																	
1	2016	Sierra	Body	Radio Controls	V																				V																																	
1	2016	Sierra	Body	HVAC Controls	V																			V	V																																	
1	2016	Sierra	Body	Radio (IO3)	V	V																		V	V																																	
1	2016	Sierra	Body	Radio (IOB)	V	V																		V	V																																	
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)	V	V																		V	V																																	
1	2016	Sierra	Body	Amplifier	V	V																			V																																	
1	2016	Sierra	Body	Media Disc Player	V	V																		V	V																																	
1	2016	Sierra	Body	Human Machine Interface Control Module	V	V																		V	V																					V													
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																	
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																	
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																	
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																	
1	2016	Sierra	Body	Seat Memory Control Module - Driver	V																																																				
1	2016	Sierra	Body	Assist Step Object Detection Control Module	V	V																		V	V																																	
1	2016	Sierra	Body	Left Side Object Detection Control Module	V																			V	V																																	
1	2016	Sierra	Body	Parking Assist Control Module	V																			V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2016	Sierra	Body	Frontview Camera Module	V	V																		V	V																																			
1	2016	Sierra	Body	Frontview Camera Module	V	V																		V	V																																			
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V													
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V												
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V										V	V	V	V									V												
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V										V	V	V	V		V																		
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
1	2016	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
1	2016	Yukon	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
1	2016	Yukon	Chassis	Power Steering Control Module	V	V																		V	V																																		
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
1	2016	Yukon	Chassis	Suspension Control Module	V	V																		V	V																																		
1	2016	Yukon	Body	Body Control Module	V	V																		V	V																																		
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
1	2016	Yukon	Body	Passenger Presence Module	V	V																			V																																		
1	2016	Yukon	Body	Instrument Cluster	V	V																		V	V																																		
1	2016	Yukon	Body	Radio Controls	V																				V																																		
1	2016	Yukon	Body	HVAC Controls	V																			V	V																																		
1	2016	Yukon	Body	Radio	V	V																		V	V																																		
1	2016	Yukon	Body	Amplifier	V	V																			V																																		
1	2016	Yukon	Body	Media Disc Player	V	V																		V	V																																		
1	2016	Yukon	Body	Human Machine Interface Control Module	V	V																		V	V																					V													
1	2016	Yukon	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
1	2016	Yukon	Body	HVAC Control Module	V	V																		V	V																																		
1	2016	Yukon	Body	Liftgate Control Module	V	V																		V	V																					V													
1	2016	Yukon	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																		
1	2016	Yukon	Body	Seat Memory Control Module - Driver	V																																																						
1	2016	Yukon	Body	Keyless Entry Control Module	V	V																		V	V																																		
1	2016	Yukon	Body	Assist Step Control Module	V	V																		V	V																																		
1	2016	Yukon	Body	Left Side Object Detection Control Module	V																			V	V																																		
1	2016	Yukon	Body	Parking Assist Control Module	V																			V	V																																		
1	2016	Yukon	Body	Frontview Camera Module	V	V																		V	V																																		
1	2016	Yukon	Body	Steering Column Lock Control Module	V	V																			V																																		
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V													
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V												
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V										V	V	V	V									V												
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V										V	V	V	V		V																		
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
1	2016	Yukon XL	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
1	2016	Yukon XL	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V		
1	2016	Yukon XL	Chassis	Power Steering Control Module	V	V																		V	V																																		
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
1	2016	Yukon XL	Chassis	Suspension Control Module	V	V																		V	V																																		
1	2016	Yukon XL	Body	Body Control Module	V	V																		V	V																																		
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
1	2016	Yukon XL	Body	Passenger Presence Module	V	V																			V																																			
1	2016	Yukon XL	Body	Instrument Cluster	V	V																		V	V																																			
1	2016	Yukon XL	Body	Radio Controls	V																				V																																			
1	2016	Yukon XL	Body	HVAC Controls	V																			V	V																																			
1	2016	Yukon XL	Body	Radio	V	V																		V	V																																			
1	2016	Yukon XL	Body	Amplifier	V	V																			V																																			
1	2016	Yukon XL	Body	Media Disc Player	V	V																		V	V																																			
1	2016	Yukon XL	Body	Human Machine Interface Control Module	V	V																		V	V																							V											
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
1	2016	Yukon XL	Body	HVAC Control Module	V	V																		V	V																																			
1	2016	Yukon XL	Body	Liftgate Control Module	V	V																		V	V																							V											
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver	V																																																							
1	2016	Yukon XL	Body	Keyless Entry Control Module	V	V																		V	V																																			
1	2016	Yukon XL	Body	Assist Step Control Module	V	V																		V	V																																			
1	2016	Yukon XL	Body	Left Side Object Detection Control Module	V																			V	V																																			
1	2016	Yukon XL	Body	Parking Assist Control Module	V																			V	V																																			
1	2016	Yukon XL	Body	Frontview Camera Module	V	V																		V	V																																			
1	2016	Yukon XL	Body	Steering Column Lock Control Module	V	V																			V																																			
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V													
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V														V													
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V																							
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V	V																							
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																							
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V		V	V	V	V	V		V	V		V	V							V														V													
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																							
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V														V													
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																							
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																			
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																			
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V											V	V	V																							
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V								V						V			V	V																																			
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module		V													V					V	V																																			
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module	V	V																		V	V																																			
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module	V	V																		V											V	V	V																							
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES	V	V																		V	V																																			
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES	V	V																		V	V																																			
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																			
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																			
2	2011	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																			
2	2011	Sierra	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
2	2011	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																			
2	2011	Sierra	Body	Body Control Module	V	V																		V	V																																			
2	2011	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																			
2	2011	Sierra	Body	Digital Radio Receiver	V	V																		V	V																																			
2	2011	Sierra	Body	Driver Door Switch	V	V																		V	V																																			
2	2011	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																			
2	2011	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																			
2	2011	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2011	Sierra	Body	Memory Seat Module	V	V																		V	V																																			
2	2011	Sierra	Body	Park Assist Module	V	V																			V																																			
2	2011	Sierra	Body	Passenger Door Switch	V	V																		V	V																																			
2	2011	Sierra	Body	Passenger Presence System	V	V																			V																																			
2	2011	Sierra	Body	Radio	V	V																		V	V																																			
2	2011	Sierra	Body	Rear Heated Seat Module	V	V																			V																																			
2	2011	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																			
2	2011	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																			
2	2011	Sierra	Body	Theft Deterrent Module	V	V																			V																																			
2	2011	Sierra Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V													
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module	V	V																		V																																			
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module		V																		V																																			
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																			
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1		V																																																				
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2		V																																																				
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module	V	V																		V										V		V																							
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module	V	V																																																					
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
2	2011	Sierra Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
2	2011	Sierra Hybrid	Body	Body Control Module	V	V																		V	V																																			
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
2	2011	Sierra Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
2	2011	Sierra Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
2	2011	Sierra Hybrid	Body	Heated Seat Module	V	V																			V																																			
2	2011	Sierra Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2011	Sierra Hybrid	Body	Park Assist Module	V	V																			V																																			
2	2011	Sierra Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
2	2011	Sierra Hybrid	Body	Passenger Presence System	V	V																			V																																			
2	2011	Sierra Hybrid	Body	Radio	V	V																		V	V																																			
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																		
2	2011	Sierra Hybrid	Body	Theft Deterrent Module	V	V																			V																																		
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module	V	V																		V	V																																		
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module	V	V																		V	V																																		
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																		
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																							
2	2011	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
2	2011	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																		
2	2011	Yukon	Chassis	Trailer Brake Control Module	V	V																		V	V																																		
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
2	2011	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																		
2	2011	Yukon	Body	Assist Step Controller	V	V																		V	V																																		
2	2011	Yukon	Body	Body Control Module	V	V																		V	V																																		
2	2011	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																		
2	2011	Yukon	Body	Digital Radio Receiver	V	V																		V	V																																		
2	2011	Yukon	Body	Driver Door Switch	V	V																		V	V																																		
2	2011	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																		
2	2011	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																		
2	2011	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																		
2	2011	Yukon	Body	Left Side Object Detection Module	V	V																		V	V																																		
2	2011	Yukon	Body	Lift Gate Module	V	V																		V	V																																		
2	2011	Yukon	Body	Memory Seat Module	V	V																		V	V																																		
2	2011	Yukon	Body	Park Assist Module	V	V																			V																																		
2	2011	Yukon	Body	Passenger Door Switch	V	V																		V	V																																		
2	2011	Yukon	Body	Passenger Presence System	V	V																			V																																		
2	2011	Yukon	Body	Radio	V	V																		V	V																																		
2	2011	Yukon	Body	Rear Heated Seat Module	V	V																			V																																		
2	2011	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																		
2	2011	Yukon	Body	Right Side Object Detection Module	V	V																			V																																		
2	2011	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																		
2	2011	Yukon	Body	Theft Deterrent Module	V	V																			V																																		
2	2011	Yukon Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V													V													
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module	V	V																		V																																		
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module		V																		V																																		
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																		
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																		
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1		V																																																				
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2		V																																																				
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module	V	V																		V										V		V																							
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module	V	V																																																				
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		
2	2011	Yukon Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2011	Yukon Hybrid	Body	Assist Step Controller	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Body Control Module	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Heated Seat Module	V	V																			V																																			
2	2011	Yukon Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Lift Gate Module	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Park Assist Module	V	V																			V																																			
2	2011	Yukon Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Passenger Presence System	V	V																			V																																			
2	2011	Yukon Hybrid	Body	Radio	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module	V	V																			V																																			
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
2	2011	Yukon Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V															
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V															
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V						V													V															
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																			
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V															
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																							
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																			
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
2	2011	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
2	2011	Yukon XL	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
2	2011	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																			
2	2011	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																			
2	2011	Yukon XL	Body	Body Control Module	V	V																		V	V																																			
2	2011	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																			
2	2011	Yukon XL	Body	Digital Radio Receiver	V	V																		V	V																																			
2	2011	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																			
2	2011	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																			
2	2011	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																			
2	2011	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2011	Yukon XL	Body	Left Side Object Detection Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2011	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																			
2	2011	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																			
2	2011	Yukon XL	Body	Park Assist Module	V	V																			V																																			
2	2011	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																			
2	2011	Yukon XL	Body	Passenger Presence System	V	V																			V																																			
2	2011	Yukon XL	Body	Radio	V	V																		V	V																																			
2	2011	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																			
2	2011	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																			
2	2011	Yukon XL	Body	Right Side Object Detection Module	V	V																			V																																			
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
2	2011	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																			
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V						V														V														
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V										V	V																									
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V																									
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V		V	V	V	V	V		V	V		V	V						V														V														
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																								
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																			
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																			
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V								V						V			V	V																																			
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module		V													V					V	V																																			
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module	V	V																		V	V																																			
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module	V	V																		V										V	V	V																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module	V	V																		V	V																																			
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES	V	V																		V	V																																			
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES	V	V																		V	V																																			
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																			
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES	V	V																		V	V																																			
2	2012	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																			
2	2012	Sierra	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
2	2012	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																			
2	2012	Sierra	Body	Body Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2012	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																			
2	2012	Sierra	Body	Digital Radio Receiver	V	V																		V	V																																			
2	2012	Sierra	Body	Driver Door Switch	V	V																		V	V																																			
2	2012	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																			
2	2012	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																			
2	2012	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2012	Sierra	Body	Memory Seat Module	V	V																		V	V																																			
2	2012	Sierra	Body	Park Assist Module	V	V																			V																																			
2	2012	Sierra	Body	Passenger Door Switch	V	V																		V	V																																			
2	2012	Sierra	Body	Passenger Presence System	V	V																			V																																			
2	2012	Sierra	Body	Radio	V	V																		V	V																																			
2	2012	Sierra	Body	Navigation Radio	V	V																		V	V																																			
2	2012	Sierra	Body	Rear Heated Seat Module	V	V																			V																																			
2	2012	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																			
2	2012	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																			
2	2012	Sierra	Body	Theft Deterrent Module	V	V																			V																																			
2	2012	Sierra Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V														
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module	V	V																		V																																			
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module		V																		V																																			
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																			
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1		V																																																					
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2		V																																																					
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module	V	V																		V										V		V																							
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module	V	V																																																					
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
2	2012	Sierra Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
2	2012	Sierra Hybrid	Body	Body Control Module	V	V																		V	V																																			
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
2	2012	Sierra Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
2	2012	Sierra Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
2	2012	Sierra Hybrid	Body	Heated Seat Module	V	V																			V																																			
2	2012	Sierra Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2012	Sierra Hybrid	Body	Park Assist Module	V	V																			V																																			
2	2012	Sierra Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
2	2012	Sierra Hybrid	Body	Passenger Presence System	V	V																			V																																			
2	2012	Sierra Hybrid	Body	Radio	V	V																		V	V																																			
2	2012	Sierra Hybrid	Body	Navigation Radio	V	V																		V	V																																			
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
2	2012	Sierra Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V														
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																							
2	2012	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
2	2012	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																			
2	2012	Yukon	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
2	2012	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																			
2	2012	Yukon	Body	Assist Step Controller	V	V																		V	V																																			
2	2012	Yukon	Body	Body Control Module	V	V																		V	V																																			
2	2012	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																			
2	2012	Yukon	Body	Digital Radio Receiver	V	V																		V	V																																			
2	2012	Yukon	Body	Driver Door Switch	V	V																		V	V																																			
2	2012	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																			
2	2012	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																			
2	2012	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2012	Yukon	Body	Left Side Object Detection Module	V	V																		V	V																																			
2	2012	Yukon	Body	Lift Gate Module	V	V																		V	V																																			
2	2012	Yukon	Body	Memory Seat Module	V	V																		V	V																																			
2	2012	Yukon	Body	Park Assist Module	V	V																			V																																			
2	2012	Yukon	Body	Passenger Door Switch	V	V																		V	V																																			
2	2012	Yukon	Body	Passenger Presence System	V	V																			V																																			
2	2012	Yukon	Body	Radio	V	V																		V	V																																			
2	2012	Yukon	Body	Navigation Radio	V	V																		V	V																																			
2	2012	Yukon	Body	Rear Heated Seat Module	V	V																			V																																			
2	2012	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																			
2	2012	Yukon	Body	Right Side Object Detection Module	V	V																			V																																			
2	2012	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																			
2	2012	Yukon	Body	Theft Deterrent Module	V	V																			V																																			
2	2012	Yukon Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V														
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module	V	V																		V																																			
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module		V																		V																																			
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																			
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1		V																																																				
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2		V																																																				
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module	V	V																		V										V		V																							
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module	V	V																																																				
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
2	2012	Yukon Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Assist Step Controller	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Body Control Module	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Driver Door Switch	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2012	Yukon Hybrid	Body	Heated Seat Module	V	V																			V																																			
2	2012	Yukon Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Lift Gate Module	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Park Assist Module	V	V																			V																																			
2	2012	Yukon Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Passenger Presence System	V	V																			V																																			
2	2012	Yukon Hybrid	Body	Radio	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Navigation Radio	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module	V	V																			V																																			
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
2	2012	Yukon Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V															
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V															
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V															
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																			
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V															
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V																		V										V	V	V																							
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																			
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
2	2012	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
2	2012	Yukon XL	Chassis	Trailer Brake Control Module	V	V																		V	V																																			
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
2	2012	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																			
2	2012	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																			
2	2012	Yukon XL	Body	Body Control Module	V	V																		V	V																																			
2	2012	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																			
2	2012	Yukon XL	Body	Digital Radio Receiver	V	V																		V	V																																			
2	2012	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																			
2	2012	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																			
2	2012	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																			
2	2012	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2012	Yukon XL	Body	Left Side Object Detection Module	V	V																		V	V																																			
2	2012	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																			
2	2012	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																			
2	2012	Yukon XL	Body	Park Assist Module	V	V																			V																																			
2	2012	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2012	Yukon XL	Body	Passenger Presence System	V	V																			V																																			
2	2012	Yukon XL	Body	Radio	V	V																		V	V																																		
2	2012	Yukon XL	Body	Navigation Radio	V	V																		V	V																																		
2	2012	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																		
2	2012	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																		
2	2012	Yukon XL	Body	Right Side Object Detection Module	V	V																			V																																		
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																		
2	2012	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																		
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V													
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																						
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module	V	V																		V	V																																		
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module	V	V																		V	V																																		
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V																						
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module	V	V																		V	V																																		
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																		
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V											V	V	V																						
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module	V	V																		V	V																																		
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																		
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V											V	V	V																						
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module	V	V																		V	V																																		
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V		V	V	V	V	V		V	V		V	V							V													V													
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																						
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																		
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V			V				V		V	V	V	V	V		V	V		V	V							V													V													
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module	V																				V																																		
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V											V	V	V																						
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module	V	V																		V	V																																		
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																		
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																						
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																		
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V								V						V			V	V																																		
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module		V													V					V	V																																		
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module	V	V																		V	V																																		
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module	V	V																		V											V	V	V																						
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module	V	V																		V	V																																		
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES	V	V																		V	V																																		
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES	V	V																		V	V																																		
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
2	2013	Sierra	Chassis	Electronic Suspension Control	V	V																		V	V																																		
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
2	2013	Sierra	Body	Amplifier (Bose)	V	V																		V	V																																		
2	2013	Sierra	Body	Body Control Module	V	V																		V	V																																		
2	2013	Sierra	Body	Body Control Module (aux.)	V	V																		V	V																																		
2	2013	Sierra	Body	Digital Radio Receiver	V	V																		V	V																																		
2	2013	Sierra	Body	Driver Door Switch	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2013	Sierra	Body	HVAC Control Module Auto	V	V																		V	V																																			
2	2013	Sierra	Body	HVAC Control Module Manual	V	V																		V	V																																			
2	2013	Sierra	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2013	Sierra	Body	Memory Seat Module	V	V																		V	V																																			
2	2013	Sierra	Body	Park Assist Module	V	V																			V																																			
2	2013	Sierra	Body	Passenger Door Switch	V	V																		V	V																																			
2	2013	Sierra	Body	Passenger Presence System	V	V																			V																																			
2	2013	Sierra	Body	Radio	V	V																		V	V																																			
2	2013	Sierra	Body	Navigation Radio	V	V																		V	V																																			
2	2013	Sierra	Body	Rear Heated Seat Module	V	V																			V																																			
2	2013	Sierra	Body	Rear HVAC/RSA	V	V																		V	V																																			
2	2013	Sierra	Body	Supplemental Inflatable Restraint	V	V																			V																																			
2	2013	Sierra	Body	Theft Deterrent Module	V	V																			V																																			
2	2013	Sierra Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V													
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module	V	V																		V																																			
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module		V																		V																																			
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																			
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																			
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1		V																																																					
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2		V																																																					
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module	V	V																		V										V		V																							
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																			
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module	V	V																																																					
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module	V	V																			V																																			
2	2013	Sierra Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																			
2	2013	Sierra Hybrid	Body	Body Control Module	V	V																		V	V																																			
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																			
2	2013	Sierra Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																			
2	2013	Sierra Hybrid	Body	Driver Door Switch	V	V																		V	V																																			
2	2013	Sierra Hybrid	Body	Heated Seat Module	V	V																			V																																			
2	2013	Sierra Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2013	Sierra Hybrid	Body	Park Assist Module	V	V																			V																																			
2	2013	Sierra Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
2	2013	Sierra Hybrid	Body	Passenger Presence System	V	V																			V																																			
2	2013	Sierra Hybrid	Body	Radio	V	V																		V	V																																			
2	2013	Sierra Hybrid	Body	Navigation Radio	V	V																		V	V																																			
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
2	2013	Sierra Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V													
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																		
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module	V	V																		V										V	V	V																							
2	2013	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
2	2013	Yukon	Chassis	Electronic Suspension Control	V	V																		V	V																																		
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
2	2013	Yukon	Body	Amplifier (Bose)	V	V																		V	V																																		
2	2013	Yukon	Body	Assist Step Controller	V	V																		V	V																																		
2	2013	Yukon	Body	Body Control Module	V	V																		V	V																																		
2	2013	Yukon	Body	Body Control Module (aux.)	V	V																		V	V																																		
2	2013	Yukon	Body	Digital Radio Receiver	V	V																		V	V																																		
2	2013	Yukon	Body	Driver Door Switch	V	V																		V	V																																		
2	2013	Yukon	Body	HVAC Control Module Auto	V	V																		V	V																																		
2	2013	Yukon	Body	HVAC Control Module Manual	V	V																		V	V																																		
2	2013	Yukon	Body	Instrument Panel Cluster	V	V																		V	V																																		
2	2013	Yukon	Body	Left Side Object Detection Module	V	V																		V	V																																		
2	2013	Yukon	Body	Lift Gate Module	V	V																		V	V																																		
2	2013	Yukon	Body	Memory Seat Module	V	V																		V	V																																		
2	2013	Yukon	Body	Park Assist Module	V	V																			V																																		
2	2013	Yukon	Body	Passenger Door Switch	V	V																		V	V																																		
2	2013	Yukon	Body	Passenger Presence System	V	V																			V																																		
2	2013	Yukon	Body	Radio	V	V																		V	V																																		
2	2013	Yukon	Body	Navigation Radio	V	V																		V	V																																		
2	2013	Yukon	Body	Rear Heated Seat Module	V	V																			V																																		
2	2013	Yukon	Body	Rear HVAC/RSA	V	V																		V	V																																		
2	2013	Yukon	Body	Right Side Object Detection Module	V	V																			V																																		
2	2013	Yukon	Body	Supplemental Inflatable Restraint	V	V																			V																																		
2	2013	Yukon	Body	Theft Deterrent Module	V	V																			V																																		
2	2013	Yukon Hybrid	Powertrain	Engine Control Module	V	V	V		V				V			V	V	V	V		V			V	V							V														V													
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module	V	V																		V																																		
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module		V																		V																																		
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module	V	V																		V	V																																		
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																		V																																		
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1		V																																																				
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2		V																																																				
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module	V	V																		V										V		V																							
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control	V	V																		V	V																																		
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																		
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module	V	V																																																				
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module	V	V																			V																																		
2	2013	Yukon Hybrid	Body	Amplifier (Bose)	V	V																		V	V																																		
2	2013	Yukon Hybrid	Body	Assist Step Controller	V	V																		V	V																																		
2	2013	Yukon Hybrid	Body	Body Control Module	V	V																		V	V																																		
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)	V	V																		V	V																																		
2	2013	Yukon Hybrid	Body	Digital Radio Receiver	V	V																		V	V																																		
2	2013	Yukon Hybrid	Body	Driver Door Switch	V	V																		V	V																																		
2	2013	Yukon Hybrid	Body	Heated Seat Module	V	V																			V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2013	Yukon Hybrid	Body	HVAC Control Module	V	V																		V	V																																			
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module	V	V																		V	V																																			
2	2013	Yukon Hybrid	Body	Lift Gate Module	V	V																		V	V																																			
2	2013	Yukon Hybrid	Body	Park Assist Module	V	V																			V																																			
2	2013	Yukon Hybrid	Body	Passenger Door Switch	V	V																		V	V																																			
2	2013	Yukon Hybrid	Body	Passenger Presence System	V	V																			V																																			
2	2013	Yukon Hybrid	Body	Radio	V	V																		V	V																																			
2	2013	Yukon Hybrid	Body	Navigation Radio	V	V																		V	V																																			
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module	V	V																			V																																			
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA	V	V																		V	V																																			
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module	V	V																			V																																			
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module	V	V																		V	V																																			
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint	V	V																			V																																			
2	2013	Yukon Hybrid	Body	Theft Deterrent Module	V	V																			V																																			
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V														
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module	V	V																		V	V																																			
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module	V	V																		V										V	V	V																							
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V														
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module	V	V																		V	V																																			
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module	V	V																		V										V	V	V																							
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module	V	V																		V	V																																			
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V														
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module	V	V																		V	V																																			
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V													V														
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module	V	V																		V	V																																			
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V	V																		V										V	V	V																							
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW	V	V																		V	V																																			
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW	V	V																		V	V																																			
2	2013	Yukon XL	Chassis	Electronic Suspension Control	V	V																		V	V																																			
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control	V	V																		V	V																																			
2	2013	Yukon XL	Body	Amplifier (Bose)	V	V																		V	V																																			
2	2013	Yukon XL	Body	Assist Step Controller	V	V																		V	V																																			
2	2013	Yukon XL	Body	Body Control Module	V	V																		V	V																																			
2	2013	Yukon XL	Body	Body Control Module (aux.)	V	V																		V	V																																			
2	2013	Yukon XL	Body	Digital Radio Receiver	V	V																		V	V																																			
2	2013	Yukon XL	Body	Driver Door Switch	V	V																		V	V																																			
2	2013	Yukon XL	Body	HVAC Control Module Auto	V	V																		V	V																																			
2	2013	Yukon XL	Body	HVAC Control Module Manual	V	V																		V	V																																			
2	2013	Yukon XL	Body	Instrument Panel Cluster	V	V																		V	V																																			
2	2013	Yukon XL	Body	Left Side Object Detection Module	V	V																		V	V																																			
2	2013	Yukon XL	Body	Lift Gate Module	V	V																		V	V																																			
2	2013	Yukon XL	Body	Memory Seat Module	V	V																		V	V																																			
2	2013	Yukon XL	Body	Park Assist Module	V	V																			V																																			
2	2013	Yukon XL	Body	Passenger Door Switch	V	V																		V	V																																			
2	2013	Yukon XL	Body	Passenger Presence System	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2013	Yukon XL	Body	Radio	V	V																		V	V																																			
2	2013	Yukon XL	Body	Navigation Radio	V	V																		V	V																																			
2	2013	Yukon XL	Body	Rear Heated Seat Module	V	V																			V																																			
2	2013	Yukon XL	Body	Rear HVAC/RSA	V	V																		V	V																																			
2	2013	Yukon XL	Body	Right Side Object Detection Module	V	V																			V																																			
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint	V	V																			V																																			
2	2013	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																			
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V				V	V	V	V	V												V														
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V				V	V	V	V	V												V														
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V												V														
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V														
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																			
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																			
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
2	2014	Sierra	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						
2	2014	Sierra	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
2	2014	Sierra	Chassis	Power Steering Control Module	V	V																		V	V																																			
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
2	2014	Sierra	Body	Body Control Module	V	V																		V	V																																			
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
2	2014	Sierra	Body	Passenger Presence Module	V	V																			V																																			
2	2014	Sierra	Body	Instrument Cluster	V	V																		V	V																																			
2	2014	Sierra	Body	Radio Control	V																				V																																			
2	2014	Sierra	Body	HVAC Control	V																			V	V																																			
2	2014	Sierra	Body	Radio	V	V																		V	V																																			
2	2014	Sierra	Body	Amplifier	V	V																			V																																			
2	2014	Sierra	Body	Media Disc Player	V	V																		V	V																																			
2	2014	Sierra	Body	Human Machine Interface Control Module	V	V																		V	V																					V														
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																			
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																			
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																			
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																			
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																			
2	2014	Sierra	Body	Parking Assist Control Module	V																			V	V																																			
2	2014	Sierra	Body	Frontview Camera Module	V	V																		V	V																																			
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V												V														
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V												V														
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module	V	V																		V																																			
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module	V																			V	V						V		V																										
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module		V								V					V					V	V																																			
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																			
2	2014	Sierra HD	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
2	2014	Sierra HD	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
2	2014	Sierra HD	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V		
2	2014	Sierra HD	Chassis	Trailer Brake Control Module	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2014	Sierra HD	Chassis	Suspension Control Module	V	V																		V	V																																			
2	2014	Sierra HD	Body	Body Control Module	V	V																		V	V																																			
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
2	2014	Sierra HD	Body	Instrument Cluster	V	V																		V	V																																		
2	2014	Sierra HD	Body	Base Radio	V	V																		V	V																																		
2	2014	Sierra HD	Body	Navigation Radio	V	V																		V	V																																		
2	2014	Sierra HD	Body	Uplevel Radio	V	V																		V	V																																		
2	2014	Sierra HD	Body	Amplifier	V	V																			V																																		
2	2014	Sierra HD	Body	Rear Audio Control Module	V	V																			V																																		
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
2	2014	Sierra HD	Body	Personal Audio Link Control Module	V																				V																																		
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																		
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)	V	V																		V	V																																		
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																		
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module	V	V																		V	V																							V											
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
2	2014	Sierra HD	Body	Seat Memory Control Module	V	V																		V	V																																		
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
2	2014	Sierra HD	Body	Parking Assist Control Module	V	V																		V	V																																		
2	2014	Sierra HD	Body	Theft Deterrent Module	V	V																			V																																		
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module	V																			V	V	V			V	V	V	V	V													V													
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module	V	V																		V	V										V	V	V	V									V												
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module	V																			V	V	V			V	V	V	V	V													V													
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V																										
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control	V	V									V									V	V							V																										
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
2	2014	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V	V						V
2	2014	Yukon	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V		
2	2014	Yukon	Chassis	Suspension Control Module	V	V																		V	V																																		
2	2014	Yukon	Body	Body Control Module	V	V																		V	V																																		
2	2014	Yukon	Body	Auxiliary Body Control Module	V	V																		V	V																																		
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
2	2014	Yukon	Body	Passenger Presence Module	V	V																			V																																		
2	2014	Yukon	Body	Instrument Cluster	V	V																		V	V																																		
2	2014	Yukon	Body	Base Radio	V	V																		V	V																																		
2	2014	Yukon	Body	Navigation Radio	V	V																		V	V																																		
2	2014	Yukon	Body	Uplevel Radio	V	V																		V	V																																		
2	2014	Yukon	Body	Amplifier	V	V																			V																																		
2	2014	Yukon	Body	Rear Audio Control Module	V	V																			V																																		
2	2014	Yukon	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
2	2014	Yukon	Body	Personal Audio Link Control Module	V																				V																																		
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)	V	V																		V	V																																		
2	2014	Yukon	Body	Driver Door Switch Panel Control Module	V	V																		V	V																							V											

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																			
2	2014	Yukon	Body	Liftgate Control Module	V	V																			V																					V													
2	2014	Yukon	Body	Seat Memory Control Module	V	V																		V	V																																		
2	2014	Yukon	Body	Rear Seat Heating Control Module	V	V																		V	V																																		
2	2014	Yukon	Body	Assist Step Control Module	V	V																		V	V																																		
2	2014	Yukon	Body	Right Side Object Detection Control Module	V	V																		V	V																																		
2	2014	Yukon	Body	Left Side Object Detection Control Module	V	V																		V	V																																		
2	2014	Yukon	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
2	2014	Yukon	Body	Parking Assist Control Module	V	V																		V	V																																		
2	2014	Yukon	Body	Theft Deterrent Module	V	V																			V																																		
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module	V																			V	V	V			V	V	V	V	V													V													
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module	V	V																		V	V										V	V	V	V									V												
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump	V	V																		V	V							V																											
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control	V	V									V									V	V							V																											
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
2	2014	Yukon XL	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						V
2	2014	Yukon XL	Chassis	Parking Brake Control Module	V	V																			V																					V							V	V	V	V			
2	2014	Yukon XL	Chassis	Suspension Control Module	V	V																		V	V																																		
2	2014	Yukon XL	Body	Body Control Module	V	V																		V	V																																		
2	2014	Yukon XL	Body	Auxiliary Body Control Module	V	V																		V	V																																		
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
2	2014	Yukon XL	Body	Passenger Presence Module	V	V																			V																																		
2	2014	Yukon XL	Body	Instrument Cluster	V	V																		V	V																																		
2	2014	Yukon XL	Body	Base Radio	V	V																		V	V																																		
2	2014	Yukon XL	Body	Navigation Radio	V	V																		V	V																																		
2	2014	Yukon XL	Body	Uplevel Radio	V	V																		V	V																																		
2	2014	Yukon XL	Body	Amplifier	V	V																			V																																		
2	2014	Yukon XL	Body	Rear Audio Control Module	V	V																			V																																		
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
2	2014	Yukon XL	Body	Personal Audio Link Control Module	V																				V																																		
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)	V	V																		V	V																																		
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module	V	V																		V	V																					V												
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module	V	V																		V	V																																		
2	2014	Yukon XL	Body	Liftgate Control Module	V	V																			V																					V												
2	2014	Yukon XL	Body	Seat Memory Control Module	V	V																		V	V																																		
2	2014	Yukon XL	Body	Rear Seat Heating Control Module	V	V																		V	V																																		
2	2014	Yukon XL	Body	Assist Step Control Module	V	V																		V	V																																		
2	2014	Yukon XL	Body	Right Side Object Detection Control Module	V	V																		V	V																																		
2	2014	Yukon XL	Body	Left Side Object Detection Control Module	V	V																		V	V																																		
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
2	2014	Yukon XL	Body	Parking Assist Control Module	V	V																		V	V																																		
2	2014	Yukon XL	Body	Theft Deterrent Module	V	V																			V																																		
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V				V	V	V	V	V													V												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V				V	V	V	V	V													V														
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V														
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V														
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V													V														
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V									V														
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V													V														
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module	V	V																		V																																			
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V										V	V	V	V									V														
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V														
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V										V	V	V	V									V														
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V										V	V	V	V		V																			
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module	V																			V	V						V		V																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module		V								V					V					V	V																																		
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)	V	V																		V	V										V	V	V	V		V																			
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)	V	V																		V	V										V	V	V	V		V																			
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																		
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																		
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																		
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																		
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																		
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)	V	V																		V	V																																		
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																		
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																		
2	2015	Sierra	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																		
2	2015	Sierra	Chassis	Power Steering Control Module	V	V																		V	V																																		
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
2	2015	Sierra	Chassis	Suspension Control Module	V	V																		V	V																																		
2	2015	Sierra	Body	Body Control Module	V	V																		V	V																																		
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
2	2015	Sierra	Body	Passenger Presence Module	V	V																			V																																		
2	2015	Sierra	Body	Instrument Cluster	V	V																		V	V																																		
2	2015	Sierra	Body	Radio Controls	V																				V																																		
2	2015	Sierra	Body	HVAC Controls	V																			V	V																																		
2	2015	Sierra	Body	Radio	V	V																		V	V																																		
2	2015	Sierra	Body	Amplifier	V	V																			V																																		
2	2015	Sierra	Body	Media Disc Player	V	V																		V	V																																		
2	2015	Sierra	Body	Human Machine Interface Control Module	V	V																		V	V																						V													
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																		
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																		
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																		
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																		
2	2015	Sierra	Body	Parking Assist Control Module	V																			V	V																																		
2	2015	Sierra	Body	Frontview Camera Module	V	V																		V	V																																		
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V														
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V														
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V														
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V										V	V	V	V									V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																			
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																	
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																	
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control	V	V																		V	V																																	
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																	
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																	
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																	
2	2015	Yukon	Powertrain	Drive Motor Control Module 1		V																			V																																	
2	2015	Yukon	Powertrain	Drive Motor Control Module 2		V																			V																																	
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump		V																			V																																	
2	2015	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																	
2	2015	Yukon	Chassis	Parking Brake Control Module	V	V																			V																					V						V	V	V	V		
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																	
2	2015	Yukon	Chassis	Power Steering Control Module	V	V																		V	V																																	
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module	V																				V																																	
2	2015	Yukon	Chassis	Suspension Control Module	V	V																		V	V																																	
2	2015	Yukon	Body	Body Control Module	V	V																		V	V																																	
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
2	2015	Yukon	Body	Passenger Presence Module	V	V																			V																																	
2	2015	Yukon	Body	Instrument Cluster	V	V																		V	V																																	
2	2015	Yukon	Body	Radio Controls	V																				V																																	
2	2015	Yukon	Body	HVAC Controls	V																			V	V																																	
2	2015	Yukon	Body	Radio	V	V																		V	V																																	
2	2015	Yukon	Body	Amplifier	V	V																			V																																	
2	2015	Yukon	Body	Media Disc Player	V	V																		V	V																																	
2	2015	Yukon	Body	Human Machine Interface Control Module	V	V																		V	V																					V												
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																	
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																	
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
2	2015	Yukon	Body	HVAC Control Module	V	V																		V	V																																	
2	2015	Yukon	Body	Liftgate Control Module	V	V																			V																					V												
2	2015	Yukon	Body	Keyless Entry Control Module	V	V																		V	V																																	
2	2015	Yukon	Body	Assist Step Control Module	V	V																		V	V																																	
2	2015	Yukon	Body	Left Side Object Detection Control Module	V																			V	V																																	
2	2015	Yukon	Body	Parking Assist Control Module	V																			V	V																																	
2	2015	Yukon	Body	Frontview Camera Module	V	V																			V																																	
2	2015	Yukon	Body	Steering Column Lock Control Module	V	V																			V																																	
2	2015	Yukon	Body	Battery Energy Control Module		V																			V																																	
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V												V												
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V												
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V												
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V												
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																		
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter	V	V																			V																																	
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control	V	V																		V	V																																	
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control	V	V																		V	V																																	
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive	V	V																		V	V																																	
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																	
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																	
2	2015	Yukon XL	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
2	2015	Yukon XL	Chassis	Parking Brake Control Module	V	V																			V																					V						V	V	V	V		
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module	V																				V																																		
2	2015	Yukon XL	Chassis	Power Steering Control Module	V	V																		V	V																																		
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module	V																				V																																		
2	2015	Yukon XL	Chassis	Suspension Control Module	V	V																		V	V																																		
2	2015	Yukon XL	Body	Body Control Module	V	V																		V	V																																		
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
2	2015	Yukon XL	Body	Passenger Presence Module	V	V																			V																																		
2	2015	Yukon XL	Body	Instrument Cluster	V	V																		V	V																																		
2	2015	Yukon XL	Body	Radio Controls	V																				V																																		
2	2015	Yukon XL	Body	HVAC Controls	V																			V	V																																		
2	2015	Yukon XL	Body	Radio	V	V																		V	V																																		
2	2015	Yukon XL	Body	Amplifier	V	V																			V																																		
2	2015	Yukon XL	Body	Media Disc Player	V	V																		V	V																																		
2	2015	Yukon XL	Body	Human Machine Interface Control Module	V	V																		V	V																					V												
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6	V	V																		V	V																																		
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																		
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
2	2015	Yukon XL	Body	HVAC Control Module	V	V																		V	V																																		
2	2015	Yukon XL	Body	Liftgate Control Module	V	V																			V																					V												
2	2015	Yukon XL	Body	Keyless Entry Control Module	V	V																		V	V																																		
2	2015	Yukon XL	Body	Assist Step Control Module	V	V																		V	V																																		
2	2015	Yukon XL	Body	Left Side Object Detection Control Module	V																			V	V																																		
2	2015	Yukon XL	Body	Parking Assist Control Module	V																			V	V																																		
2	2015	Yukon XL	Body	Frontview Camera Module	V	V																			V																																		
2	2015	Yukon XL	Body	Steering Column Lock Control Module	V	V																			V																																		
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module	V																			V	V				V	V	V	V	V												V													
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module	V																			V	V				V	V	V	V	V												V													
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module	V	V																		V	V										V	V	V	V									V											
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V												V													
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed	V	V																		V	V										V	V	V	V								V													
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed	V	V																		V	V										V	V	V	V		V																	
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module	V																			V	V				V	V	V	V	V												V													
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module	V	V																		V	V										V	V	V	V		V																		
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module	V	V	V	V																V	V																																		
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2	V	V																		V	V																																		
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V				V	V	V	V	V												V													
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V								V													
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V												V													
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module	V	V																		V																																		
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V										V	V	V	V								V													
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V													
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V										V	V	V	V								V													
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V										V	V	V	V		V																	
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module	V																			V	V						V		V																									
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module		V								V					V					V	V																																		
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module	V	V																		V	V										V	V	V	V		V																	
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module	V	V																		V	V																																		
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)	V	V																		V	V																																		
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																				
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																				
2	2016	Sierra	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V								
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																				
2	2016	Sierra	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V			
2	2016	Sierra	Chassis	Power Steering Control Module	V	V																			V																																				
2	2016	Sierra	Chassis	Power Steering Control Module	V	V																		V	V																																				
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module	V																				V																																				
2	2016	Sierra	Chassis	Suspension Control Module	V	V																		V	V																																				
2	2016	Sierra	Body	Body Control Module	V	V																		V	V																																				
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																				
2	2016	Sierra	Body	Passenger Presence Module	V	V																			V																																				
2	2016	Sierra	Body	Instrument Cluster	V	V																		V	V																																				
2	2016	Sierra	Body	Radio Controls	V																				V																																				
2	2016	Sierra	Body	HVAC Controls	V																			V	V																																				
2	2016	Sierra	Body	Radio (IO3)	V	V																		V	V																																				
2	2016	Sierra	Body	Radio (IOB)	V	V																		V	V																																				
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)	V	V																		V	V																																				
2	2016	Sierra	Body	Amplifier	V	V																			V																																				
2	2016	Sierra	Body	Media Disc Player	V	V																		V	V																																				
2	2016	Sierra	Body	Human Machine Interface Control Module	V	V																		V	V																					V															
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7	V	V																		V	V																																				
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																				
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)	V	V																		V	V																																				
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)	V	V																		V	V																																				
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)	V	V																		V	V																																				
2	2016	Sierra	Body	Seat Memory Control Module - Driver	V																																																								
2	2016	Sierra	Body	Assist Step Object Detection Control Module	V	V																		V	V																																				
2	2016	Sierra	Body	Left Side Object Detection Control Module	V																			V	V																																				
2	2016	Sierra	Body	Parking Assist Control Module	V																			V	V																																				
2	2016	Sierra	Body	Frontview Camera Module	V	V																		V	V																																				
2	2016	Sierra	Body	Frontview Camera Module	V	V																		V	V																																				
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V												V																
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V									V	V	V	V									V															
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V												V																
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V									V	V	V	V									V															
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V									V	V	V	V		V																					
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																				
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																				
2	2016	Yukon	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V								
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																				
2	2016	Yukon	Chassis	Parking Brake Control Module	V	V																			V																						V							V	V	V	V			
2	2016	Yukon	Chassis	Power Steering Control Module	V	V																		V	V																																				
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module	V																				V																																				
2	2016	Yukon	Chassis	Suspension Control Module	V	V																		V	V																																				
2	2016	Yukon	Body	Body Control Module	V	V																		V	V																																				
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																				
2	2016	Yukon	Body	Passenger Presence Module	V	V																			V																																				
2	2016	Yukon	Body	Instrument Cluster	V	V																		V	V																																				
2	2016	Yukon	Body	Radio Controls	V																				V																																				
2	2016	Yukon	Body	HVAC Controls	V																			V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
2	2016	Yukon	Body	Radio	V	V																		V	V																																			
2	2016	Yukon	Body	Amplifier	V	V																			V																																			
2	2016	Yukon	Body	Media Disc Player	V	V																		V	V																																			
2	2016	Yukon	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
2	2016	Yukon	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
2	2016	Yukon	Body	HVAC Control Module	V	V																		V	V																																			
2	2016	Yukon	Body	Liftgate Control Module	V	V																		V	V																						V												
2	2016	Yukon	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
2	2016	Yukon	Body	Seat Memory Control Module - Driver	V																																																							
2	2016	Yukon	Body	Keyless Entry Control Module	V	V																		V	V																																			
2	2016	Yukon	Body	Assist Step Control Module	V	V																		V	V																																			
2	2016	Yukon	Body	Left Side Object Detection Control Module	V																			V	V																																			
2	2016	Yukon	Body	Parking Assist Control Module	V																			V	V																																			
2	2016	Yukon	Body	Frontview Camera Module	V	V																		V	V																																			
2	2016	Yukon	Body	Steering Column Lock Control Module	V	V																			V																																			
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module	V																			V	V				V	V	V	V	V													V													
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module	V																			V	V				V	V	V	V	V													V												
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed	V	V																		V	V										V	V	V	V									V												
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed	V	V																		V	V										V	V	V	V			V																		
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)	V	V																		V	V																																			
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)	V	V																		V	V																																			
2	2016	Yukon XL	Chassis	Electronic Brake Control Module	V	V																		V	V												V										V	V	V	V	V	V						
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module	V	V																			V																																			
2	2016	Yukon XL	Chassis	Parking Brake Control Module	V	V																			V																					V								V	V	V	V			
2	2016	Yukon XL	Chassis	Power Steering Control Module	V	V																		V	V																																			
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module	V																				V																																			
2	2016	Yukon XL	Chassis	Suspension Control Module	V	V																		V	V																																			
2	2016	Yukon XL	Body	Body Control Module	V	V																		V	V																																			
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
2	2016	Yukon XL	Body	Passenger Presence Module	V	V																			V																																			
2	2016	Yukon XL	Body	Instrument Cluster	V	V																		V	V																																			
2	2016	Yukon XL	Body	Radio Controls	V																				V																																			
2	2016	Yukon XL	Body	HVAC Controls	V																			V	V																																			
2	2016	Yukon XL	Body	Radio	V	V																		V	V																																			
2	2016	Yukon XL	Body	Amplifier	V	V																			V																																			
2	2016	Yukon XL	Body	Media Disc Player	V	V																		V	V																																			
2	2016	Yukon XL	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
2	2016	Yukon XL	Body	HVAC Control Module	V	V																		V	V																																			
2	2016	Yukon XL	Body	Liftgate Control Module	V	V																		V	V																						V												
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger	V	V																		V	V																																			
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver	V																																																						
2	2016	Yukon XL	Body	Keyless Entry Control Module	V	V																		V	V																																			
2	2016	Yukon XL	Body	Assist Step Control Module	V	V																		V	V																																			
2	2016	Yukon XL	Body	Left Side Object Detection Control Module	V																			V	V																																			
2	2016	Yukon XL	Body	Parking Assist Control Module	V																			V	V																																			
2	2016	Yukon XL	Body	Frontview Camera Module	V	V																		V	V																																			
2	2016	Yukon XL	Body	Steering Column Lock Control Module	V	V																			V																																			
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V											V	V																							

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																			
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																		
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module	V	V																		V										V	V																								
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																		
5	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
5	2011	ALL	Body	Body Control Module	V	V																		V	V																																		
5	2011	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
5	2011	ALL	Body	Generator Battery Control Module	V	V																		V	V																																		
5	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
5	2011	ALL	Body	Passenger Presence System																																																						
5	2011	ALL	Body	Personal Audio Link Module	V																				V																																		
5	2011	ALL	Body	Base Radio	V	V																			V																																		
5	2011	ALL	Body	Uplevel Radio	V	V																			V																																		
5	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
5	2011	ALL	Body	Theft Deterrent Module	V	V																																																				
5	2011	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																								
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																		
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																		
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module	V	V																		V										V	V																								
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																		
5	2012	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
5	2012	ALL	Body	Body Control Module	V	V																		V	V																																		
5	2012	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
5	2012	ALL	Body	Generator Battery Control Module	V	V																		V	V																																		
5	2012	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
5	2012	ALL	Body	Passenger Presence System																																																					
5	2012	ALL	Body	Personal Audio Link Module	V																				V																																		
5	2012	ALL	Body	Base Radio	V	V																			V																																		
5	2012	ALL	Body	Uplevel Radio	V	V																			V																																		
5	2012	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
5	2012	ALL	Body	Theft Deterrent Module	V	V																																																				
5	2012	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																											
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V														
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V									V	V	V	V										V												
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V													
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V									V													
5	2015	Canyon	Powertrain	Chassis Control Module	V	V									V									V	V							V																										
5	2015	Canyon	Powertrain	Transfer Case Control Module	V	V																		V	V																																	
5	2015	Canyon	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V					V
5	2015	Canyon	Chassis	Power Steering Control Module	V	V																			V																																	
5	2015	Canyon	Body	Body Control Module	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																				
5	2015	Canyon	Body	Passenger Presence Module	V	V																			V																																				
5	2015	Canyon	Body	Radio	V	V																		V	V																																			
5	2015	Canyon	Body	Amplifier	V	V																			V																																			
5	2015	Canyon	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
5	2015	Canyon	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
5	2015	Canyon	Body	Parking Assist Control Module	V																			V	V																																			
5	2015	Canyon	Body	Frontview Camera Module	V	V																		V	V																																			
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V	V																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V	V												V														
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V									V	V	V	V										V												
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module	V																			V	V																																			
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module	V	V																		V	V									V	V	V	V										V												
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V										V												
5	2016	Canyon	Powertrain	Transfer Case Control Module	V	V																		V	V																																			
5	2016	Canyon	Chassis	Electronic Brake Control Module	V	V																		V	V												V												V	V	V	V	V	V						V
5	2016	Canyon	Chassis	Power Steering Control Module	V	V																			V																																			
5	2016	Canyon	Body	Body Control Module	V	V																		V	V																																			
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																			
5	2016	Canyon	Body	Passenger Presence Module	V	V																			V																																			
5	2016	Canyon	Body	Trailer Interface Control Module	V	V																		V	V																																			
5	2016	Canyon	Body	Radio	V	V																		V	V																																			
5	2016	Canyon	Body	Amplifier	V	V																			V																																			
5	2016	Canyon	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
5	2016	Canyon	Body	Telematics Communication Interface Control Module	V	V																		V	V																																			
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																			
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																			
5	2016	Canyon	Body	Frontview Camera Module	V	V																		V	V																																			
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																								
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																			
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module	V																			V																																				
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																			
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module	V																			V																																				
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V														
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module	V	V																		V										V	V																								
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																			
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module	V																			V																																				
6	2011	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																			
6	2011	ALL	Body	Body Control Module	V	V																		V	V																																			
6	2011	ALL	Body	Digital Radio Receiver	V	V																		V	V																																			
6	2011	ALL	Body	Generator Battery Control Module	V	V																		V	V																																			
6	2011	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
6	2011	ALL	Body	Passenger Presence System	V																																																						
6	2011	ALL	Body	Personal Audio Link Module	V																				V																																			
6	2011	ALL	Body	Base Radio	V	V																			V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
6	2011	ALL	Body	Uplevel Radio	V	V																			V																																			
6	2011	ALL	Body	Supplemental Inflatable Restraint	V	V																																																					
6	2011	ALL	Body	Theft Deterrent Module	V	V																																																					
6	2011	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module	V	V																		V										V	V																								
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module	V	V																		V	V																																		
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module	V																			V																																			
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																		
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module	V																			V																																			
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V																				V													
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module	V	V																		V										V	V																								
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																		
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module	V																			V																																			
6	2012	ALL	Chassis	Electronic Brake Control Module	V	V																		V	V																																		
6	2012	ALL	Body	Body Control Module	V	V																		V	V																																		
6	2012	ALL	Body	Digital Radio Receiver	V	V																		V	V																																		
6	2012	ALL	Body	Generator Battery Control Module	V	V																		V	V																																		
6	2012	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
6	2012	ALL	Body	Passenger Presence System	V																																																					
6	2012	ALL	Body	Personal Audio Link Module	V																				V																																		
6	2012	ALL	Body	Base Radio	V	V																			V																																		
6	2012	ALL	Body	Uplevel Radio	V	V																			V																																		
6	2012	ALL	Body	Supplemental Inflatable Restraint	V	V																																																				
6	2012	ALL	Body	Theft Deterrent Module	V	V																																																				
6	2012	ALL	Body	Vehicle Comm. Interface Module	V	V																		V	V																																		
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V													V													
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V									V	V	V	V											V											
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission	V																			V	V				V	V	V	V	V							V	V	V	V		V													
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V									V	V	V	V										V											
6	2015	Canyon	Powertrain	Chassis Control Module	V	V									V									V	V							V																										
6	2015	Canyon	Powertrain	Transfer Case Control Module	V	V																		V	V																																		
6	2015	Canyon	Chassis	Electronic Brake Control Module	V	V																		V	V												V												V	V	V	V	V	V					V
6	2015	Canyon	Chassis	Power Steering Control Module	V	V																			V																																		
6	2015	Canyon	Body	Body Control Module	V	V																		V	V																																		
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
6	2015	Canyon	Body	Passenger Presence Module	V	V																			V																																		
6	2015	Canyon	Body	Radio	V	V																		V	V																																		
6	2015	Canyon	Body	Amplifier	V	V																			V																																		
6	2015	Canyon	Body	Human Machine Interface Control Module	V	V																		V	V																									V									
6	2015	Canyon	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																		
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																		
6	2015	Canyon	Body	Parking Assist Control Module	V																			V	V																																		
6	2015	Canyon	Body	Frontview Camera Module	V	V																		V	V																																		
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission	V																			V	V	V	V	V	V	V	V	V																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission	V																			V	V	V	V	V	V	V	V	V												V														

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module	V	V																		V	V										V	V	V	V									V												
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module	V																			V	V																																		
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module	V	V																		V	V										V	V	V	V									V												
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module	V																			V	V				V	V	V	V	V							V	V	V	V	V	V													
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module	V	V																		V	V										V	V	V	V									V												
6	2016	Canyon	Powertrain	Transfer Case Control Module	V	V																		V	V																																	
6	2016	Canyon	Chassis	Electronic Brake Control Module	V	V																		V	V													V											V	V	V	V	V	V					V
6	2016	Canyon	Chassis	Power Steering Control Module	V	V																			V																																	
6	2016	Canyon	Body	Body Control Module	V	V																		V	V																																	
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																	
6	2016	Canyon	Body	Passenger Presence Module	V	V																			V																																	
6	2016	Canyon	Body	Trailer Interface Control Module	V	V																		V	V																																	
6	2016	Canyon	Body	Radio	V	V																		V	V																																	
6	2016	Canyon	Body	Amplifier	V	V																			V																																	
6	2016	Canyon	Body	Human Machine Interface Control Module	V	V																		V	V																						V												
6	2016	Canyon	Body	Telematics Communication Interface Control Module	V	V																		V	V																																	
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)	V	V																		V	V																																	
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)	V	V																		V	V																																	
6	2016	Canyon	Body	Frontview Camera Module	V	V																		V	V																																	
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V												
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																					
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V												
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																					
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V												
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																	
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																					
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V												
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																					
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V												
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V											V	V	V																					
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																	
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																	
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																	
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V											V	V	V																					
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																	
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																	
7	2011	Express/Savana	Body	Body Control Module	V	V																		V	V																																	
7	2011	Express/Savana	Body	Digital Radio Receiver	V	V																		V	V																																	
7	2011	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																	
7	2011	Express/Savana	Body	Passenger Presence System	V	V																			V																																	
7	2011	Express/Savana	Body	Radio	V	V																		V	V																																	
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
7	2011	Express/Savana	Body	Rollover Sensor	V	V																			V																																	
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																	
7	2011	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																	
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V													V												
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																					
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V												
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																					
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V												
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																	

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																							
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																					
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V														V												
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V											V	V	V																					
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																	
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																	
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																	
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V											V	V	V																					
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																	
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																	
7	2011	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																	
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver	V	V																		V	V																																	
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																	
7	2011	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																	
7	2011	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																	
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
7	2011	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																	
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																	
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																	
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V												
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																					
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																	
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																							
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																					
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V														V												
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V											V	V	V																					
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																	
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																	
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																	
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V											V	V	V																					
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																	
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																	
7	2012	Express/Savana	Body	Body Control Module	V	V																		V	V																																	
7	2012	Express/Savana	Body	Digital Radio Receiver	V	V																		V	V																																	
7	2012	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																	
7	2012	Express/Savana	Body	Passenger Presence System	V	V																			V																																	
7	2012	Express/Savana	Body	Radio	V	V																		V	V																																	
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
7	2012	Express/Savana	Body	Rollover Sensor	V	V																			V																																	
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																	
7	2012	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																	
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V												
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																							
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																					
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Right Front Solenoid Valves	ABS Left Front Solenoid Valves	ABS Right Rear Solenoid Valves	ABS Left Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																						
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																					
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V														V												
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V											V	V	V																					
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																		
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																		
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																		
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V											V	V	V																					
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
7	2012	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver	V	V																		V	V																																		
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
7	2012	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																		
7	2012	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																		
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
7	2012	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																		
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																		
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																		
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V												
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																						
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																					
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																						
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																					
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V														V												
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V											V	V	V																					
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																		
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																		
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																		
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V											V	V	V																					
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
7	2013	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
7	2013	Express/Savana	Body	Digital Radio Receiver	V	V																		V	V																																		
7	2013	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
7	2013	Express/Savana	Body	Passenger Presence System	V	V																			V																																		
7	2013	Express/Savana	Body	Radio	V	V																		V	V																																		
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
7	2013	Express/Savana	Body	Rollover Sensor	V	V																			V																																		
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																		
7	2013	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																		
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V												
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module	V	V																		V											V	V																						
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V														V												
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																					

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V													
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V													
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																						
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module		V																		V	V																																		
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V								V						V			V	V																																		
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module		V													V					V	V																																		
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module	V	V																		V										V	V	V																						
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
7	2013	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver	V	V																		V	V																																		
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
7	2013	Express Access/Savana Pro	Body	Navigation Radio	V	V																		V	V																																		
7	2013	Express Access/Savana Pro	Body	Park Assist Module	V	V																			V																																		
7	2013	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																		
7	2013	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																		
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
7	2013	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																		
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																		
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																		
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module	V																			V	V			V	V	V	V	V													V													
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module	V	V																		V	V									V	V	V	V	V								V													
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V												V													
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module	V																			V	V	V			V	V	V	V	V												V													
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module	V	V																		V	V							V		V																									
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module	V	V																		V	V									V	V	V	V	V								V													
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V												V													
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V	V			V	V	V	V	V												V													
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																									
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																		
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V									V	V	V	V									V													
7	2014	Savana	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						V
7	2014	Savana	Body	Body Control Module	V	V																		V	V																																		
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
7	2014	Savana	Body	Passenger Presence Module	V	V																			V																																		
7	2014	Savana	Body	Rollover Sensor Module	V	V																			V																																		
7	2014	Savana	Body	Instrument Cluster	V	V																		V	V																																		
7	2014	Savana	Body	Chime Alarm Control Module	V																			V	V																																		
7	2014	Savana	Body	Base Radio	V	V																		V	V																																		
7	2014	Savana	Body	Navigation Radio	V	V																		V	V																																		
7	2014	Savana	Body	Uplevel Radio	V	V																		V	V																																		
7	2014	Savana	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
7	2014	Savana	Body	Auxiliary Heater Control Module		V																		V																																			
7	2014	Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
7	2014	Savana	Body	Parking Assist Control Module	V																			V	V																																		
7	2014	Savana	Body	Theft Deterrent Module	V	V																			V																																		
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																		
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V										V	V	V	V									V												
7	2015	Savana	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
7	2015	Savana	Body	Body Control Module	V	V																		V	V																																		
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
7	2015	Savana	Body	Rollover Sensor Module	V	V																			V																																		
7	2015	Savana	Body	Instrument Cluster	V	V																		V	V																																		
7	2015	Savana	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
7	2015	Savana	Body	Auxiliary Heater Control Module		V																		V																																			
7	2015	Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
7	2015	Savana	Body	Parking Assist Control Module	V																			V	V																																		
7	2015	Savana	Body	Theft Deterrent Module	V	V																			V																																		
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V	V			V	V	V	V	V													V												
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V										V	V	V	V									V												
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																		
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V										V	V	V	V									V												
7	2016	Savana	Chassis	Electronic Brake Control Module	V	V																		V	V													V										V	V	V	V	V	V						V
7	2016	Savana	Body	Body Control Module	V	V																		V	V																																		
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
7	2016	Savana	Body	Instrument Cluster	V	V																		V	V																																		
7	2016	Savana	Body	Chime Alarm Control Module	V																			V	V																																		
7	2016	Savana	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
7	2016	Savana	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
7	2016	Savana	Body	Auxiliary Heater Control Module		V																		V																																			
7	2016	Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
7	2016	Savana	Body	Parking Assist Control Module	V																			V	V																																		
7	2016	Savana	Body	Theft Deterrent Module	V	V																			V																																		
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V												
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																						
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V												
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																	
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V												

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																							
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V														
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V											V	V	V																						
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
8	2011	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
8	2011	Express/Savana	Body	Digital Radio Receiver	V	V																		V	V																																		
8	2011	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
8	2011	Express/Savana	Body	Passenger Presence System	V	V																			V																																		
8	2011	Express/Savana	Body	Radio	V	V																		V	V																																		
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
8	2011	Express/Savana	Body	Rollover Sensor	V	V																			V																																		
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																		
8	2011	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																		
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																						
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																						
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																						
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V														
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V											V	V	V																						
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
8	2011	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver	V	V																		V	V																																		
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
8	2011	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																		
8	2011	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																		
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
8	2011	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																		
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																		
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																		
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V											V	V	V																						
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V											V	V																						
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V							V													V														
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V											V	V	V																						
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V														
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V											V	V	V																						
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
8	2012	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
8	2012	Express/Savana	Body	Digital Radio Receiver	V	V																		V	V																																		
8	2012	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
8	2012	Express/Savana	Body	Passenger Presence System	V	V																			V																																		
8	2012	Express/Savana	Body	Radio	V	V																		V	V																																		
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Right Front Solenoid Valves	ABS Left Front Solenoid Valves	ABS Right Rear Solenoid Valves	ABS Left Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
8	2012	Express/Savana	Body	Rollover Sensor	V	V																			V																																			
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																			
8	2012	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																			
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																						
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V						V														V													
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																						
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
8	2012	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																		
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver	V	V																		V	V																																		
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																		
8	2012	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																		
8	2012	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																		
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
8	2012	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																		
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																		
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																		
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																						
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																						
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V						V														V													
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																						
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																		
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																		
8	2013	Express/Savana	Body	Body Control Module	V	V																		V	V																																		
8	2013	Express/Savana	Body	Digital Radio Receiver	V	V																		V	V																																		
8	2013	Express/Savana	Body	Instrument Panel Cluster	V	V																		V	V																																		
8	2013	Express/Savana	Body	Navigation Radio	V	V																		V	V																																		
8	2013	Express/Savana	Body	Park Assist Module	V	V																			V																																		
8	2013	Express/Savana	Body	Passenger Presence System	V	V																			V																																		
8	2013	Express/Savana	Body	Radio	V	V																		V	V																																		
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
8	2013	Express/Savana	Body	Rollover Sensor	V	V																			V																																		
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint	V	V																			V																																		
8	2013	Express/Savana	Body	Theft Deterrent Module	V	V																			V																																		
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module	V	V																		V										V	V	V																						
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module	V	V																		V	V																																		
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module	V	V																		V										V	V																							
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V	V			V				V	V	V	V		V	V		V	V		V	V						V														V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module	V	V																		V										V	V	V																							
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V	V	V		V						V	V	V	V	V		V	V		V	V							V													V													
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module	V	V																		V										V	V	V																						
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES	V	V																		V	V																																	
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES	V	V																		V	V																																	
8	2013	Express Access/Savana Pro	Body	Body Control Module	V	V																		V	V																																	
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver	V	V																		V	V																																	
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster	V	V																		V	V																																	
8	2013	Express Access/Savana Pro	Body	Navigation Radio	V	V																		V	V																																	
8	2013	Express Access/Savana Pro	Body	Park Assist Module	V	V																			V																																	
8	2013	Express Access/Savana Pro	Body	Passenger Presence System	V	V																			V																																	
8	2013	Express Access/Savana Pro	Body	Radio	V	V																		V	V																																	
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
8	2013	Express Access/Savana Pro	Body	Rollover Sensor	V	V																			V																																	
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V	V																			V																																	
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module	V	V																			V																																	
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module	V																			V	V			V	V	V	V	V													V													
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module	V	V																		V	V									V	V	V	V	V									V											
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V													V													
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module	V	V																		V	V									V	V	V	V										V													
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module	V																			V	V	V			V	V	V	V	V													V													
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module	V	V																		V	V							V		V																									
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module	V	V																		V	V										V	V	V	V	V									V													
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V													V													
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V	V			V	V	V	V	V													V													
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																									
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																	
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V									V	V	V	V									V													
8	2014	Savana	Chassis	Electronic Brake Control Module	V	V																		V	V												V											V	V	V	V	V	V						V
8	2014	Savana	Body	Body Control Module	V	V																		V	V																																	
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																	
8	2014	Savana	Body	Passenger Presence Module	V	V																			V																																	
8	2014	Savana	Body	Rollover Sensor Module	V	V																			V																																	
8	2014	Savana	Body	Instrument Cluster	V	V																		V	V																																	
8	2014	Savana	Body	Chime Alarm Control Module	V																			V	V																																	
8	2014	Savana	Body	Base Radio	V	V																		V	V																																	
8	2014	Savana	Body	Navigation Radio	V	V																		V	V																																	
8	2014	Savana	Body	Uplevel Radio	V	V																		V	V																																	
8	2014	Savana	Body	Digital Radio Receiver Control Module	V	V																		V	V																																	
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																	
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																	
8	2014	Savana	Body	Auxiliary Heater Control Module		V																		V																																	
8	2014	Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																	
8	2014	Savana	Body	Parking Assist Control Module	V																			V	V																																	
8	2014	Savana	Body	Theft Deterrent Module	V	V																			V																																	
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V													V													
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module	V	V																		V	V									V	V	V	V									V													
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V													V													
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V									V	V	V	V									V													

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V	V			V	V	V	V	V												V															
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																											
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																			
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V										V	V	V	V									V													
8	2015	Savana	Chassis	Electronic Brake Control Module	V	V																		V	V													V											V	V	V	V	V	V						V
8	2015	Savana	Body	Body Control Module	V	V																		V	V																																			
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																			V																																		
8	2015	Savana	Body	Rollover Sensor Module	V	V																			V																																		
8	2015	Savana	Body	Instrument Cluster	V	V																		V	V																																		
8	2015	Savana	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9	V	V																		V	V																																		
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10	V	V																		V	V																																		
8	2015	Savana	Body	Auxiliary Heater Control Module		V																		V																																			
8	2015	Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
8	2015	Savana	Body	Parking Assist Control Module	V																			V	V																																		
8	2015	Savana	Body	Theft Deterrent Module	V	V																			V																																		
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module	V																			V	V	V			V	V	V	V	V												V															
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module	V																			V	V	V			V	V	V	V	V												V															
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module	V																			V	V				V	V	V	V	V												V															
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module	V	V																		V	V										V	V	V	V									V													
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V																			V	V						V		V																											
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module		V								V					V					V	V																																			
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module	V	V																		V	V										V	V	V	V									V													
8	2016	Savana	Chassis	Electronic Brake Control Module	V	V																		V	V													V											V	V	V	V	V	V						V
8	2016	Savana	Body	Body Control Module	V	V																		V	V																																		
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module	V	V																		V	V																																		
8	2016	Savana	Body	Instrument Cluster	V	V																		V	V																																		
8	2016	Savana	Body	Chime Alarm Control Module	V																			V	V																																		
8	2016	Savana	Body	Digital Radio Receiver Control Module	V	V																		V	V																																		
8	2016	Savana	Body	Telematics Communication Interface Control Module	V	V																		V	V																																		
8	2016	Savana	Body	Auxiliary Heater Control Module		V																		V																																			
8	2016	Savana	Body	Remote Control Door Lock Receiver	V	V																		V	V																																		
8	2016	Savana	Body	Parking Assist Control Module	V																			V	V																																		
8	2016	Savana	Body	Theft Deterrent Module	V	V																			V																																		
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module	V	V										V	V				V	V		V	V							V												V															
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module	V	V																		V										V	V																								
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module	V	V																		V																																		
ALL	2004	ALL	Chassis	ABS	V	V																		V																																		
ALL	2004	ALL	Chassis	Air Suspension	V	V																		V	V																																		
ALL	2004	ALL	Body	Amplifier (Bose)	V	V																			V																																		
ALL	2004	ALL	Body	Body Control Module	V	V																		V	V																																		
ALL	2004	ALL	Body	Digital Radio Receiver	V	V																			V																																		
ALL	2004	ALL	Body	Driver Door Module	V	V																		V	V																																		
ALL	2004	ALL	Body	Driver Seat Module	V	V																		V	V																																		
ALL	2004	ALL	Body	Heating and Air Conditioning	V	V																		V	V																																		
ALL	2004	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																		
ALL	2004	ALL	Body	OnStar	V	V																		V	V																																		
ALL	2004	ALL	Body	Passenger Door Module	V	V																		V	V																																		

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
ALL	2004	ALL	Body	Uplevel Radio	V	V																			V																																				
ALL	2004	ALL	Body	Navigation Radio	V	V																		V																																				
ALL	2004	ALL	Body	Rear Seat Audio	V	V																			V																																				
ALL	2004	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module	V	V																		V										V	V																								
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module	V	V																		V																																				
ALL	2005	ALL	Chassis	ABS	V	V																		V																																				
ALL	2005	ALL	Chassis	Air Suspension	V	V																		V	V																																			
ALL	2005	ALL	Body	Body Control Module	V	V																		V	V																																			
ALL	2005	ALL	Body	Digital Radio Receiver	V	V																			V																																			
ALL	2005	ALL	Body	Driver Door Module (SUV)	V	V																		V	V																																			
ALL	2005	ALL	Body	Driver Door Module (SUT)	V	V																		V	V																																			
ALL	2005	ALL	Body	Driver Seat Module	V	V																		V	V																																			
ALL	2005	ALL	Body	Heating and Air Conditioning	V	V																		V	V																																			
ALL	2005	ALL	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2005	ALL	Body	Passenger Door Module	V	V																		V	V																																			
ALL	2005	ALL	Body	Uplevel Radio	V	V																			V																																				
ALL	2005	ALL	Body	Navigation Radio	V	V																		V																																				
ALL	2005	ALL	Body	Rear Seat Audio	V	V																			V																																				
ALL	2005	ALL	Body	Supplemental Inflatable Restraint	V	V																																																						
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module	V	V																		V										V	V																								
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module	V	V																		V																																				
ALL	2006	H2	Chassis	ABS	V	V																		V																																				
ALL	2006	H2	Chassis	Air Suspension	V	V																		V	V																																			
ALL	2006	H2	Body	Body Control Module	V	V																		V	V																																			
ALL	2006	H2	Body	Digital Radio Receiver	V	V																			V																																			
ALL	2006	H2	Body	Driver Door Module (SUV)	V	V																		V	V																																			
ALL	2006	H2	Body	Driver Door Module (SUT)	V	V																		V	V																																			
ALL	2006	H2	Body	Driver Seat Module	V	V																		V	V																																			
ALL	2006	H2	Body	Heating and Air Conditioning	V	V																		V	V																																			
ALL	2006	H2	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2006	H2	Body	Passenger Door Module	V	V																		V	V																																			
ALL	2006	H2	Body	Uplevel Radio	V	V																			V																																				
ALL	2006	H2	Body	Navigation Radio	V	V																		V																																				
ALL	2006	H2	Body	Rear Seat Audio	V	V																			V																																				
ALL	2006	H2	Body	Supplemental Inflatable Restraint	V	V																																																						
ALL	2006	H3	Powertrain	Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V													V														
ALL	2006	H3	Powertrain	Transmission Control Module	V	V																		V										V	V																								
ALL	2006	H3	Powertrain	Transfer Case Control Module	V	V																		V																																				
ALL	2006	H3	Chassis	Antilock Brake System	V	V																		V	V																																			
ALL	2006	H3	Body	Body Control Module	V	V																		V	V																																			
ALL	2006	H3	Body	Digital Radio Receiver	V	V																			V																																			
ALL	2006	H3	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2006	H3	Body	Uplevel Radio	V	V																		V																																				
ALL	2006	H3	Body	Navigation Radio	V	V																		V	V																																			
ALL	2006	H3	Body	Supplemental Inflatable Restraint	V	V																			V																																				
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module	V	V										V	V				V	V		V	V							V													V														
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module	V	V																		V										V	V																								
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module	V	V																		V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
ALL	2007	H2	Chassis	ABS	V	V																		V																																						
ALL	2007	H2	Chassis	Air Suspension	V	V																		V	V																																				
ALL	2007	H2	Body	Amplifier (Bose)	V	V																			V																																				
ALL	2007	H2	Body	Body Control Module	V	V																		V	V																																				
ALL	2007	H2	Body	Digital Radio Receiver	V	V																			V																																				
ALL	2007	H2	Body	Driver Door Module (SUV)	V	V																		V	V																																				
ALL	2007	H2	Body	Driver Door Module (SUT)	V	V																		V	V																																				
ALL	2007	H2	Body	Driver Seat Module	V	V																		V	V																																				
ALL	2007	H2	Body	HVAC Control Module	V	V																		V	V																																				
ALL	2007	H2	Body	Instrument Panel Cluster	V	V																		V	V																																				
ALL	2007	H2	Body	Passenger Door Module	V	V																		V	V																																				
ALL	2007	H2	Body	Uplevel Radio	V	V																			V																																				
ALL	2007	H2	Body	Navigation Radio	V	V																		V																																				
ALL	2007	H2	Body	Rear Seat Audio	V	V																			V																																				
ALL	2007	H2	Body	Supplemental Inflatable Restraint	V	V																																																						
ALL	2007	H2	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module	V	V	V						V			V	V	V			V	V		V	V							V														V														
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module	V	V																		V											V	V																								
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module	V	V																		V																																				
ALL	2007	H3	Chassis	EBCM	V	V																		V	V																																				
ALL	2007	H3	Body	Body Control Module (5GT)	V	V																		V	V																																				
ALL	2007	H3	Body	Body Control Module (ADM)	V	V																		V	V																																				
ALL	2007	H3	Body	Digital Radio Receiver	V	V																			V																																				
ALL	2007	H3	Body	Generator Battery Control Module	V	V																		V	V																																				
ALL	2007	H3	Body	Instrument Panel Cluster	V	V																		V	V																																				
ALL	2007	H3	Body	Personal Audio Link Module	V																				V																																				
ALL	2007	H3	Body	Uplevel Radio	V	V																		V																																				
ALL	2007	H3	Body	Navigation Radio	V	V																		V	V																																				
ALL	2007	H3	Body	Supplemental Inflatable Restraint	V	V																			V																																				
ALL	2007	H3	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module	V	V	V		V				V			V	V	V			V	V		V	V							V														V														
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																				
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																								
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																				
ALL	2008	H2	Chassis	Air SCM	V	V																		V	V																																				
ALL	2008	H2	Chassis	EBCM	V	V																		V	V																																				
ALL	2008	H2	Body	Amplifier (Bose)	V	V																		V	V																																				
ALL	2008	H2	Body	Body Control Module	V	V																		V	V																																				
ALL	2008	H2	Body	Digital Radio Receiver	V	V																			V																																				
ALL	2008	H2	Body	Driver Door Switch	V	V																		V	V																																				
ALL	2008	H2	Body	HVAC Control Module	V	V																		V	V																																				
ALL	2008	H2	Body	Instrument Panel Cluster	V	V																		V	V																																				
ALL	2008	H2	Body	Memory Seat Module	V	V																		V	V																																				
ALL	2008	H2	Body	Passenger Door Switch	V	V																		V	V																																				
ALL	2008	H2	Body	Radio	V	V																		V	V																																				
ALL	2008	H2	Body	Rear Heated Seat Module	V	V																			V																																				
ALL	2008	H2	Body	Rear HVAC/RSA	V	V																		V	V																																				
ALL	2008	H2	Body	Rollover Sensor	V	V																			V																																				
ALL	2008	H2	Body	Supplemental Inflatable Restraint	V	V																			V																																				
ALL	2008	H2	Body	Theft Deterrent Module	V	V																			V																																				
ALL	2008	H2	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)	V	V	V		V				V			V	V	V	V		V	V		V	V							V												V	V															
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V														
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module	V	V																		V											V	V																								
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module	V	V																		V																																				
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V														
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module	V	V																		V											V	V																								
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module	V	V																		V																																				
ALL	2008	H3	Chassis	EBCM	V	V																		V	V																																			
ALL	2008	H3	Body	Body Control Module (5GT)	V	V																		V	V																																			
ALL	2008	H3	Body	Body Control Module (ADM)	V	V																		V	V																																			
ALL	2008	H3	Body	Digital Radio Receiver	V	V																			V																																			
ALL	2008	H3	Body	Generator Battery Control Module	V	V																		V	V																																			
ALL	2008	H3	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2008	H3	Body	Personal Audio Link Module	V																				V																																			
ALL	2008	H3	Body	Uplevel Radio	V	V																		V																																			
ALL	2008	H3	Body	Navigation Radio	V	V																		V	V																																			
ALL	2008	H3	Body	Supplemental Inflatable Restraint	V	V																			V																																			
ALL	2008	H3	Body	Theft Deterrent Module	V	V																																																					
ALL	2008	H3	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module	V	V	V						V			V	V	V	V		V	V		V	V							V														V														
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module	V	V																		V											V	V	V																							
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																			
ALL	2009	H2	Chassis	Air SCM	V	V																		V	V																																			
ALL	2009	H2	Chassis	EBCM	V	V																		V	V																																			
ALL	2009	H2	Body	Amplifier (Bose)	V	V																		V	V																																			
ALL	2009	H2	Body	Body Control Module	V	V																		V	V																																			
ALL	2009	H2	Body	Digital Radio Receiver	V	V																		V	V																																			
ALL	2009	H2	Body	Driver Door Switch	V	V																		V	V																																			
ALL	2009	H2	Body	HVAC Control Module	V	V																		V	V																																			
ALL	2009	H2	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2009	H2	Body	Memory Seat Module	V	V																		V	V																																			
ALL	2009	H2	Body	Passenger Door Switch	V	V																		V	V																																			
ALL	2009	H2	Body	Radio	V	V																		V	V																																			
ALL	2009	H2	Body	Rear Heated Seat Module	V	V																			V																																			
ALL	2009	H2	Body	Rear HVAC/RSA	V	V																		V	V																																			
ALL	2009	H2	Body	Rollover Sensor	V	V																			V																																			
ALL	2009	H2	Body	Supplemental Inflatable Restraint	V	V																			V																																			
ALL	2009	H2	Body	Theft Deterrent Module	V	V																			V																																			
ALL	2009	H2	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
ALL	2009	H2	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V	V														
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)	V	V	V		V				V			V	V	V	V		V	V		V	V							V														V														
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																			
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module	V	V																		V											V	V																								
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)	V	V																		V																																				
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)	V	V																		V																																				
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)	V	V	V						V			V	V	V	V		V	V		V	V							V														V														
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)	V	V	V						V			V	V	V	V		V	V		V	V							V														V														
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module	V	V																		V	V																																			
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module	V	V																		V											V	V																								

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)	V	V																		V																																				
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)	V	V																		V																																				
ALL	2009	H3	Chassis	EBCM	V	V																		V	V																																			
ALL	2009	H3	Body	Body Control Module (5GN/5GT)	V	V																		V	V																																			
ALL	2009	H3	Body	Body Control Module (ADM)	V	V																		V	V																																			
ALL	2009	H3	Body	Digital Radio Receiver	V	V																		V	V																																			
ALL	2009	H3	Body	Generator Battery Control Module	V	V																		V	V																																			
ALL	2009	H3	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2009	H3	Body	Personal Audio Link Module	V																				V																																			
ALL	2009	H3	Body	Uplevel Radio	V	V																		V																																			
ALL	2009	H3	Body	Navigation Radio	V	V																		V	V																																			
ALL	2009	H3	Body	Supplemental Inflatable Restraint	V	V																			V																																			
ALL	2009	H3	Body	Theft Deterrent Module	V	V																																																					
ALL	2009	H3	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module	V	V	V		V				V	V	V	V		V	V		V	V		V	V							V													V														
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module	V	V																		V	V																																			
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module	V	V																		V										V	V	V																							
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module	V	V																		V	V																																			
ALL	2010	H2	Chassis	Air SCM	V	V																		V	V																																			
ALL	2010	H2	Chassis	EBCM	V	V																		V	V																																			
ALL	2010	H2	Body	Amplifier (Bose)	V	V																		V	V																																			
ALL	2010	H2	Body	Body Control Module	V	V																		V	V																																			
ALL	2010	H2	Body	Digital Radio Receiver	V	V																		V	V																																			
ALL	2010	H2	Body	Driver Door Switch	V	V																		V	V																																			
ALL	2010	H2	Body	HVAC Control Module	V	V																		V	V																																			
ALL	2010	H2	Body	Instrument Panel Cluster	V	V																		V	V																																			
ALL	2010	H2	Body	Memory Seat Module	V	V																		V	V																																			
ALL	2010	H2	Body	Passenger Door Switch	V	V																		V	V																																			
ALL	2010	H2	Body	Personal Audio Link Module	V																				V																																			
ALL	2010	H2	Body	Radio	V	V																		V	V																																			
ALL	2010	H2	Body	Rear Heated Seat Module	V	V																			V																																			
ALL	2010	H2	Body	Rear HVAC/RSA	V	V																		V	V																																			
ALL	2010	H2	Body	Rollover Sensor	V	V																			V																																			
ALL	2010	H2	Body	Supplemental Inflatable Restraint	V	V																			V																																			
ALL	2010	H2	Body	Theft Deterrent Module	V	V																			V																																			
ALL	2010	H2	Body	Vehicle Comm. Interface Module	V	V																		V	V																																			
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V	V													
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module	V	V																		V	V																																			
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module	V	V																		V										V	V																								
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)	V	V																		V																																				
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)	V	V																		V																																				
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module	V	V	V		V				V			V	V	V	V		V	V		V	V							V													V														
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module	V	V																		V	V																																			
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module	V	V																		V										V	V																								
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)	V	V																		V																																				
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)	V	V																		V																																				
ALL	2010	H3	Chassis	EBCM	V	V																		V	V																																			
ALL	2010	H3	Body	Body Control Module	V	V																		V	V																																			
ALL	2010	H3	Body	Digital Radio Receiver	V	V																		V	V																																			
ALL	2010	H3	Body	Generator Battery Control Module	V	V																		V	V																																			
ALL	2010	H3	Body	Instrument Panel Cluster	V	V																		V	V																																			

Engine type	Year	Model	System 1	System 2	DTC Analysis	Data Analysis	Engine Data	Automatic Transmission Data	CMP Actuator Data	Engine Cooling and HVAC Data	Cruise Control+ PTO and Traction Control Data	Electrical and Immobilizer Data	EVAP Data	Exhaust Aftertreatment Data	Fuel System Data	Fuel Trim Data	HO2S Data	Ignition Data	Induction Data	Instrument Cluster Data	Misfire Data	TAC Data	Fuel Alcohol Content Event Data	Actuator	ECU Information Display	Intake Camshaft Position Actuator	Exhaust Camshaft Position Actuator	Crankshaft Position Variation Learn	HO2S Heater Learn	Idle Learn	Engine Oil Life Reset	Fuel Trim Reset	Remote Vehicle Start Disable History Reset	Fuel Pump Data	Transmission Data	TCC Data	Shift Data	Solenoid Valve Data	Steady State Adaptive Pressure Data	Transmission Adaptive Values Learn	Intake CMP Actuator Bank 1	Exhaust CMP Actuator Bank 1	Intake CMP Actuator Bank 2	Exhaust CMP Actuator Bank 2	Clutch Pedal Position Learn	Crankshaft Pos. Variation Learn	Transmission Adaptive Pressure Reset	Data Display	Antilock Braking Data	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	Park Brake Cable Replacement Procedure	Park Brake Cable Service Apply	Park Brake Cable Service Release	Park Brake Calibration	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn
ALL	2010	H3	Body	Personal Audio Link Module	V																				V																																					
ALL	2010	H3	Body	Uplevel Radio	V	V																		V																																					
ALL	2010	H3	Body	Navigation Radio	V	V																		V	V																																				
ALL	2010	H3	Body	Supplemental Inflatable Restraint	V	V																			V																																				
ALL	2010	H3	Body	Theft Deterrent Module	V	V																																																							
ALL	2010	H3	Body	Vehicle Comm. Interface Module	V	V																		V	V																																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																							
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																							
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																							
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																							
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																							
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																							
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																							
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																							
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																							
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																							
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																							
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																							
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																							
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																							
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																							
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																							
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																							
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																							
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																							
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																							
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																							
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																							
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																							
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																							
C	2004	ALL	Chassis	ESC																																																						
C	2004	ALL	Chassis	Rear Wheel Steering																																																							
C	2004	ALL	Chassis	Tire Pressure Monitor																																																							
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																							
C	2004	ALL	Chassis	VSES																																																						
C	2004	ALL	Body	Amplifier (Bose)																																																						
C	2004	ALL	Body	Body Control Module																															V																								
C	2004	ALL	Body	CD Changer																																																						
C	2004	ALL	Body	Chime																																																						
C	2004	ALL	Body	Driver Door Module																																																						
C	2004	ALL	Body	Driver Seat Module																																																						
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																						
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																						
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																						
C	2004	ALL	Body	Instrument Panel Cluster																																																						
C	2004	ALL	Body	OnStar																																	V																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2004	ALL	Body	Passenger Door Module																																																												
C	2004	ALL	Body	Passenger Presence System																																																												
C	2004	ALL	Body	Radio Base																																																												
C	2004	ALL	Body	Radio Uplevel																																																												
C	2004	ALL	Body	Radio Navigation																																																												
C	2004	ALL	Body	Rear Aux. Climate Module																																																												
C	2004	ALL	Body	Rear HVAC																																																												
C	2004	ALL	Body	Rear Seat Audio																																																												
C	2004	ALL	Body	Rear Seat Entertainment																																																												
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2004	ALL	Body	Vehicle Theft Deterrent																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																												
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
C	2005	ALL	Chassis	ESC																																																											
C	2005	ALL	Chassis	Rear Wheel Steering																																																												
C	2005	ALL	Chassis	Tire Pressure Monitor																																																												
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2005	ALL	Chassis	VSES																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2005	ALL	Body	Amplifier (Bose)																																																								
C	2005	ALL	Body	Body Control Module																														V																											
C	2005	ALL	Body	CD Changer																																																								
C	2005	ALL	Body	Chime																																																								
C	2005	ALL	Body	Disc Player and Video Display																																																								
C	2005	ALL	Body	Driver Door Module																																																								
C	2005	ALL	Body	Driver Seat Module																																																								
C	2005	ALL	Body	Generator Battery Control Module																																																								
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																								
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																								
C	2005	ALL	Body	Instrument Panel Cluster																																																								
C	2005	ALL	Body	Passenger Door Module																																																								
C	2005	ALL	Body	Passenger Presence System																																																								
C	2005	ALL	Body	Base Radio																																																								
C	2005	ALL	Body	Uplevel Radio																																																								
C	2005	ALL	Body	Navigation Radio																																																								
C	2005	ALL	Body	Rear Aux. Climate Module																																																								
C	2005	ALL	Body	Rear HVAC																																																								
C	2005	ALL	Body	Rear Seat Audio																																																								
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2005	ALL	Body	Vehicle Comm. Interface Module																																V																										
C	2005	ALL	Body	Vehicle Theft Deterrent																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																								
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																								
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																								
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																								
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																											
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																											
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																											
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
C	2006	ALL	Chassis	ESC																																																										
C	2006	ALL	Chassis	Tire Pressure Monitor																																																											
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2006	ALL	Chassis	VSES																																																										
C	2006	ALL	Body	Amplifier (Bose)																																																											
C	2006	ALL	Body	Body Control Module																														V																													
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																										
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																	V																									
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Sierra	Chassis	Electronic Suspension Control																																																										
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																										
C	2007	Sierra	Body	Amplifier (Bose)																																																										
C	2007	Sierra	Body	Body Control Module																																																										
C	2007	Sierra	Body	Body Control Module (aux.)																																																										
C	2007	Sierra	Body	Digital Radio Receiver																																																										
C	2007	Sierra	Body	Driver Door Switch																																																										
C	2007	Sierra	Body	HVAC Control Module Auto																																												V														
C	2007	Sierra	Body	HVAC Control Module Manual																																												V														
C	2007	Sierra	Body	Instrument Panel Cluster																																																										
C	2007	Sierra	Body	Memory Seat Module																																																										
C	2007	Sierra	Body	Park Assist Module																																																										
C	2007	Sierra	Body	Passenger Door Switch																																																										
C	2007	Sierra	Body	Passenger Presence System																																																										
C	2007	Sierra	Body	Radio																																																										
C	2007	Sierra	Body	Rear Heated Seat Module																																																										
C	2007	Sierra	Body	Rear HVAC/RSA																																																										
C	2007	Sierra	Body	Rollover Sensor																																																										
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2007	Sierra	Body	Theft Deterrent Module																																																										
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Yukon	Chassis	Electronic Suspension Control																																																										
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																										
C	2007	Yukon	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2007	Yukon	Body	Assist Step Controller																																																								
C	2007	Yukon	Body	Body Control Module																																																								
C	2007	Yukon	Body	Body Control Module (aux.)																																																								
C	2007	Yukon	Body	Digital Radio Receiver																																																								
C	2007	Yukon	Body	Driver Door Switch																																																								
C	2007	Yukon	Body	HVAC Control Module Auto																																												V												
C	2007	Yukon	Body	HVAC Control Module Manual																																												V												
C	2007	Yukon	Body	Instrument Panel Cluster																																																								
C	2007	Yukon	Body	Lift Gate Module																																																								
C	2007	Yukon	Body	Memory Seat Module																																																								
C	2007	Yukon	Body	Park Assist Module																																																								
C	2007	Yukon	Body	Passenger Door Switch																																																								
C	2007	Yukon	Body	Passenger Presence System																																																								
C	2007	Yukon	Body	Radio																																																								
C	2007	Yukon	Body	Rear Heated Seat Module																																																								
C	2007	Yukon	Body	Rear HVAC/RSA																																																								
C	2007	Yukon	Body	Rollover Sensor																																																								
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																																								
C	2007	Yukon	Body	Theft Deterrent Module																																																								
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																								
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																								
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																								
C	2007	Yukon XL	Body	Amplifier (Bose)																																																								
C	2007	Yukon XL	Body	Assist Step Controller																																																								
C	2007	Yukon XL	Body	Body Control Module																																																								
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																								
C	2007	Yukon XL	Body	Digital Radio Receiver																																																								
C	2007	Yukon XL	Body	Driver Door Switch																																																								
C	2007	Yukon XL	Body	HVAC Control Module Auto																																												V												
C	2007	Yukon XL	Body	HVAC Control Module Manual																																												V												
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																								
C	2007	Yukon XL	Body	Lift Gate Module																																																								
C	2007	Yukon XL	Body	Memory Seat Module																																																								
C	2007	Yukon XL	Body	Park Assist Module																																																								
C	2007	Yukon XL	Body	Passenger Door Switch																																																								
C	2007	Yukon XL	Body	Passenger Presence System																																																								
C	2007	Yukon XL	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2007	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2007	Yukon XL	Body	Rollover Sensor																																																												
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2007	Yukon XL	Body	Theft Deterrent Module																																																												
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Sierra	Chassis	Electronic Suspension Control																																																												
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2008	Sierra	Body	Amplifier (Bose)																																																												
C	2008	Sierra	Body	Body Control Module																																																												
C	2008	Sierra	Body	Body Control Module (aux.)																																																												
C	2008	Sierra	Body	Digital Radio Receiver																																																												
C	2008	Sierra	Body	Driver Door Switch																																																												
C	2008	Sierra	Body	HVAC Control Module Auto																																													V															
C	2008	Sierra	Body	HVAC Control Module Manual																																													V															
C	2008	Sierra	Body	Instrument Panel Cluster																																																												
C	2008	Sierra	Body	Memory Seat Module																																																												
C	2008	Sierra	Body	Park Assist Module																																																												
C	2008	Sierra	Body	Passenger Door Switch																																																												
C	2008	Sierra	Body	Passenger Presence System																																																												
C	2008	Sierra	Body	Radio																																																											
C	2008	Sierra	Body	Rear Heated Seat Module																																																												
C	2008	Sierra	Body	Rear HVAC/RSA																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2008	Sierra	Body	Rollover Sensor																																																												
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2008	Sierra	Body	Theft Deterrent Module																																																												
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Yukon	Chassis	Electronic Brake Control Module																																																												
C	2008	Yukon	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon	Body	Amplifier (Bose)																																																												
C	2008	Yukon	Body	Assist Step Controller																																																												
C	2008	Yukon	Body	Body Control Module																																																												
C	2008	Yukon	Body	Body Control Module (aux.)																																																												
C	2008	Yukon	Body	Digital Radio Receiver																																																												
C	2008	Yukon	Body	Driver Door Switch																																																												
C	2008	Yukon	Body	HVAC Control Module Auto																																													V															
C	2008	Yukon	Body	HVAC Control Module Manual																																													V															
C	2008	Yukon	Body	Instrument Panel Cluster																																																												
C	2008	Yukon	Body	Lift Gate Module																																																												
C	2008	Yukon	Body	Memory Seat Module																																																												
C	2008	Yukon	Body	Park Assist Module																																																												
C	2008	Yukon	Body	Passenger Door Switch																																																												
C	2008	Yukon	Body	Passenger Presence System																																																												
C	2008	Yukon	Body	Radio																																																											
C	2008	Yukon	Body	Rear Heated Seat Module																																																												
C	2008	Yukon	Body	Rear HVAC/RSA																																																												
C	2008	Yukon	Body	Rollover Sensor																																																												
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon	Body	Theft Deterrent Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																									
C	2008	Yukon Hybrid	Body	Body Control Module																																																										
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																										
C	2008	Yukon Hybrid	Body	HVAC Control Module																																												V														
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2008	Yukon Hybrid	Body	Lift Gate Module																																																										
C	2008	Yukon Hybrid	Body	Memory Seat Module																																																										
C	2008	Yukon Hybrid	Body	Park Assist Module																																																										
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																										
C	2008	Yukon Hybrid	Body	Passenger Presence System																																																										
C	2008	Yukon Hybrid	Body	Radio																																																										
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																										
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																										
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon XL	Body	Amplifier (Bose)																																																										
C	2008	Yukon XL	Body	Assist Step Controller																																																										
C	2008	Yukon XL	Body	Body Control Module																																																										
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2008	Yukon XL	Body	Digital Radio Receiver																																																										
C	2008	Yukon XL	Body	Driver Door Switch																																																										
C	2008	Yukon XL	Body	HVAC Control Module Auto																																												V														
C	2008	Yukon XL	Body	HVAC Control Module Manual																																												V														
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2008	Yukon XL	Body	Lift Gate Module																																																										
C	2008	Yukon XL	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2008	Yukon XL	Body	Park Assist Module																																																											
C	2008	Yukon XL	Body	Passenger Door Switch																																																												
C	2008	Yukon XL	Body	Passenger Presence System																																																												
C	2008	Yukon XL	Body	Radio																																																												
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2008	Yukon XL	Body	Rollover Sensor																																																												
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon XL	Body	Theft Deterrent Module																																																												
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual																																																												
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2009	Sierra	Chassis	Electronic Suspension Control																																																												
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2009	Sierra	Body	Amplifier (Bose)																																																												
C	2009	Sierra	Body	Body Control Module																																																												
C	2009	Sierra	Body	Body Control Module (aux.)																																																												
C	2009	Sierra	Body	Digital Radio Receiver																																																												
C	2009	Sierra	Body	Driver Door Switch																																																												
C	2009	Sierra	Body	HVAC Control Module Auto																																													V															

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2009	Sierra	Body	HVAC Control Module Manual																																												V												
C	2009	Sierra	Body	Instrument Panel Cluster																																																							
C	2009	Sierra	Body	Memory Seat Module																																																							
C	2009	Sierra	Body	Park Assist Module																																																							
C	2009	Sierra	Body	Passenger Door Switch																																																							
C	2009	Sierra	Body	Passenger Presence System																																																							
C	2009	Sierra	Body	Radio																																																							
C	2009	Sierra	Body	Rear Heated Seat Module																																																							
C	2009	Sierra	Body	Rear HVAC/RSA																																																							
C	2009	Sierra	Body	Rollover Sensor																																																							
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																																							
C	2009	Sierra	Body	Theft Deterrent Module																																																							
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																							
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																							
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																							
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																							
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																							
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																							
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																							
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																							
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																							
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																							
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																							
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																							
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																							
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																							
C	2009	Sierra Hybrid	Body	Body Control Module																																																							
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																							
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																							
C	2009	Sierra Hybrid	Body	Driver Door Switch																																																							
C	2009	Sierra Hybrid	Body	HVAC Control Module																																												V												
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																							
C	2009	Sierra Hybrid	Body	Memory Seat Module																																																							
C	2009	Sierra Hybrid	Body	Park Assist Module																																																							
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																																							
C	2009	Sierra Hybrid	Body	Passenger Presence System																																																							
C	2009	Sierra Hybrid	Body	Radio																																																							
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																							
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																							
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																							
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																							
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																							
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																							
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed																																																							
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed																																																							
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																							
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																							
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																							
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																							
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																							
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
C	2009	Yukon	Chassis	Electronic Brake Control Module																																																												
C	2009	Yukon	Chassis	Electronic Suspension Control																																																												
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																												
C	2009	Yukon	Body	Amplifier (Bose)																																																												
C	2009	Yukon	Body	Assist Step Controller																																																												
C	2009	Yukon	Body	Body Control Module																																																												
C	2009	Yukon	Body	Body Control Module (aux.)																																																												
C	2009	Yukon	Body	Digital Radio Receiver																																																												
C	2009	Yukon	Body	Driver Door Switch																																																												
C	2009	Yukon	Body	HVAC Control Module Auto																																												V																
C	2009	Yukon	Body	HVAC Control Module Manual																																												V																
C	2009	Yukon	Body	Instrument Panel Cluster																																																												
C	2009	Yukon	Body	Left Side Object Detection Module																																																												
C	2009	Yukon	Body	Lift Gate Module																																																												
C	2009	Yukon	Body	Memory Seat Module																																																												
C	2009	Yukon	Body	Park Assist Module																																																												
C	2009	Yukon	Body	Passenger Door Switch																																																												
C	2009	Yukon	Body	Passenger Presence System																																																												
C	2009	Yukon	Body	Radio																																																												
C	2009	Yukon	Body	Rear Heated Seat Module																																																												
C	2009	Yukon	Body	Rear HVAC/RSA																																																												
C	2009	Yukon	Body	Right Side Object Detection Module																																																												
C	2009	Yukon	Body	Rollover Sensor																																																												
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																																												
C	2009	Yukon	Body	Theft Deterrent Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																												
C	2009	Yukon Hybrid	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2009	Yukon Hybrid	Body	Driver Door Switch																																																										
C	2009	Yukon Hybrid	Body	Heated Seat Module																																																										
C	2009	Yukon Hybrid	Body	HVAC Control Module																																												V														
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
C	2009	Yukon Hybrid	Body	Park Assist Module																																																										
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																																										
C	2009	Yukon Hybrid	Body	Passenger Presence System																																																										
C	2009	Yukon Hybrid	Body	Radio																																																										
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																										
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																										
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2009	Yukon XL	Body	Amplifier (Bose)																																																										
C	2009	Yukon XL	Body	Assist Step Controller																																																										
C	2009	Yukon XL	Body	Body Control Module																																																										
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2009	Yukon XL	Body	Digital Radio Receiver																																																										
C	2009	Yukon XL	Body	Driver Door Switch																																																										
C	2009	Yukon XL	Body	HVAC Control Module Auto																																												V														
C	2009	Yukon XL	Body	HVAC Control Module Manual																																												V														
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2009	Yukon XL	Body	Left Side Object Detection Module																																																										
C	2009	Yukon XL	Body	Lift Gate Module																																																										
C	2009	Yukon XL	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2009	Yukon XL	Body	Park Assist Module																																																											
C	2009	Yukon XL	Body	Passenger Door Switch																																																												
C	2009	Yukon XL	Body	Passenger Presence System																																																												
C	2009	Yukon XL	Body	Radio																																																												
C	2009	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2009	Yukon XL	Body	Right Side Object Detection Module																																																												
C	2009	Yukon XL	Body	Rollover Sensor																																																												
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2009	Yukon XL	Body	Theft Deterrent Module																																																												
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2010	Sierra	Chassis	Electronic Suspension Control																																																												
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra	Body	Amplifier (Bose)																																																												
C	2010	Sierra	Body	Body Control Module																																																											
C	2010	Sierra	Body	Body Control Module (aux.)																																																												
C	2010	Sierra	Body	Digital Radio Receiver																																																												
C	2010	Sierra	Body	Driver Door Switch																																																												
C	2010	Sierra	Body	HVAC Control Module Auto																																													V															
C	2010	Sierra	Body	HVAC Control Module Manual																																													V															
C	2010	Sierra	Body	Instrument Panel Cluster																																																												
C	2010	Sierra	Body	Memory Seat Module																																																												
C	2010	Sierra	Body	Park Assist Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2010	Sierra	Body	Passenger Door Switch																																																									
C	2010	Sierra	Body	Passenger Presence System																																																										
C	2010	Sierra	Body	Radio																																																										
C	2010	Sierra	Body	Rear Heated Seat Module																																																										
C	2010	Sierra	Body	Rear HVAC/RSA																																																										
C	2010	Sierra	Body	Supplemental Inflatable Restraint																									V	V																																
C	2010	Sierra	Body	Theft Deterrent Module																																																										
C	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																										
C	2010	Sierra Hybrid	Body	Body Control Module																																																										
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																										
C	2010	Sierra Hybrid	Body	Driver Door Switch																																																										
C	2010	Sierra Hybrid	Body	Heated Seat Module																																																										
C	2010	Sierra Hybrid	Body	HVAC Control Module																																												V																
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
C	2010	Sierra Hybrid	Body	Park Assist Module																																																										
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																																										
C	2010	Sierra Hybrid	Body	Passenger Presence System																																																										
C	2010	Sierra Hybrid	Body	Radio																																																										
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Yukon	Chassis	Electronic Brake Control Module																																																										
C	2010	Yukon	Chassis	Electronic Suspension Control																																																										
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon	Body	Amplifier (Bose)																																																										
C	2010	Yukon	Body	Assist Step Controller																																																										
C	2010	Yukon	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2010	Yukon	Body	Body Control Module (aux.)																																																												
C	2010	Yukon	Body	Digital Radio Receiver																																																													
C	2010	Yukon	Body	Driver Door Switch																																																													
C	2010	Yukon	Body	HVAC Control Module Auto																																												V																
C	2010	Yukon	Body	HVAC Control Module Manual																																												V																
C	2010	Yukon	Body	Instrument Panel Cluster																																																													
C	2010	Yukon	Body	Left Side Object Detection Module																																																													
C	2010	Yukon	Body	Lift Gate Module																																																													
C	2010	Yukon	Body	Memory Seat Module																																																													
C	2010	Yukon	Body	Park Assist Module																																																													
C	2010	Yukon	Body	Passenger Door Switch																																																													
C	2010	Yukon	Body	Passenger Presence System																																																													
C	2010	Yukon	Body	Radio																																																													
C	2010	Yukon	Body	Rear Heated Seat Module																																																													
C	2010	Yukon	Body	Rear HVAC/RSA																																																													
C	2010	Yukon	Body	Right Side Object Detection Module																																																													
C	2010	Yukon	Body	Supplemental Inflatable Restraint																									V	V																																			
C	2010	Yukon	Body	Theft Deterrent Module																																																													
C	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																													
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																													
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																													
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																													
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																													
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																													
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																													
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																													
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																													
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																													
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																													
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																													
C	2010	Yukon Hybrid	Body	Body Control Module																																																													
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																													
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																													
C	2010	Yukon Hybrid	Body	Driver Door Switch																																																													
C	2010	Yukon Hybrid	Body	Heated Seat Module																																																													
C	2010	Yukon Hybrid	Body	HVAC Control Module																																												V																
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																													
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																													
C	2010	Yukon Hybrid	Body	Lift Gate Module																																																													
C	2010	Yukon Hybrid	Body	Park Assist Module																																																													
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																																													
C	2010	Yukon Hybrid	Body	Passenger Presence System																																																													
C	2010	Yukon Hybrid	Body	Radio																																																													
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																													
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																													
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																													
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																													
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																			

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																									
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																										
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																										
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2010	Yukon XL	Body	Amplifier (Bose)																																																										
C	2010	Yukon XL	Body	Assist Step Controller																																																										
C	2010	Yukon XL	Body	Body Control Module																																																										
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2010	Yukon XL	Body	Digital Radio Receiver																																																										
C	2010	Yukon XL	Body	Driver Door Switch																																																										
C	2010	Yukon XL	Body	HVAC Control Module Auto																																												V														
C	2010	Yukon XL	Body	HVAC Control Module Manual																																												V														
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2010	Yukon XL	Body	Left Side Object Detection Module																																																										
C	2010	Yukon XL	Body	Lift Gate Module																																																										
C	2010	Yukon XL	Body	Memory Seat Module																																																										
C	2010	Yukon XL	Body	Park Assist Module																																																										
C	2010	Yukon XL	Body	Passenger Door Switch																																																										
C	2010	Yukon XL	Body	Passenger Presence System																																																										
C	2010	Yukon XL	Body	Radio																																																										
C	2010	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2010	Yukon XL	Body	Right Side Object Detection Module																																																										
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																								V	V																																
C	2010	Yukon XL	Body	Theft Deterrent Module																																																										
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																										
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																										
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2008	ALL	Chassis	Electronic Brake Control Module																																																										
D	2008	ALL	Body	Body Control Module																																																										
D	2008	ALL	Body	Body Control Module (aux.)																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
D	2008	ALL	Body	Headlamp Control Module																																																									
D	2008	ALL	Body	HVAC Control Module Auto																																																									
D	2008	ALL	Body	Instrument Panel Cluster																																																									
D	2008	ALL	Body	Park Assist Module																																																									
D	2008	ALL	Body	Remote Control Door Lock Receiver																																																									
D	2008	ALL	Body	Supplemental Inflatable Restraint																																																									
D	2008	ALL	Body	Theft Deterrent Module																																																									
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																									
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																									
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																									
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																									
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																									
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																									
D	2009	ALL	Chassis	Electronic Brake Control Module																																																									
D	2009	ALL	Body	Body Control Module																																																									
D	2009	ALL	Body	Body Control Module (aux.)																																																									
D	2009	ALL	Body	Headlamp Control Module																																																									
D	2009	ALL	Body	HVAC Control Module Auto																																																									
D	2009	ALL	Body	Instrument Panel Cluster																																																									
D	2009	ALL	Body	Park Assist Module																																																									
D	2009	ALL	Body	Remote Control Door Lock Receiver																																																									
D	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
D	2009	ALL	Body	Theft Deterrent Module																																																									
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																									
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																									
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																									
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																									
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																									
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																									
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																									
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																									
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																									
D	2010	ALL	Chassis	Electronic Brake Control Module																																																									
D	2010	ALL	Body	Body Control Module																																																									
D	2010	ALL	Body	Body Control Module (aux.)																																																									
D	2010	ALL	Body	Headlamp Control Module																																																									
D	2010	ALL	Body	HVAC Control Module Auto																																																									
D	2010	ALL	Body	Instrument Panel Cluster																																																									
D	2010	ALL	Body	Park Assist Module																																																									
D	2010	ALL	Body	Remote Control Door Lock Receiver																																																									
D	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																								
G	2004	Express/Savana	Chassis	VSES																																																								
G	2004	Express/Savana	Body	Body Control Module																															V																									
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2004	Express/Savana	Body	OnStar																																V																								
G	2004	Express/Savana	Body	Base Radio																																																								
G	2004	Express/Savana	Body	Uplevel Radio																																																								
G	2004	Express/Savana	Body	Remote Function Actuation																																																								
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
G	2004	Express Access/Savana Pro	Chassis	VSES																																																								
G	2004	Express Access/Savana Pro	Body	Body Control Module																															V																									
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
G	2004	Express Access/Savana Pro	Body	OnStar																																V																								
G	2004	Express Access/Savana Pro	Body	Base Radio																																																								
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																								
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																								
G	2005	Express/Savana	Chassis	VSES																																																								
G	2005	Express/Savana	Body	Body Control Module																														V																										
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2005	Express/Savana	Body	Base Radio																																																								
G	2005	Express/Savana	Body	Uplevel Radio																																																								
G	2005	Express/Savana	Body	Remote Function Actuation																																																								
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																V																								
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
G	2005	Express Access/Savana Pro	Chassis	VSES																																																								
G	2005	Express Access/Savana Pro	Body	Body Control Module																														V																										
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
G	2005	Express Access/Savana Pro	Body	Base Radio																																																								
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																								
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																V																								
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2006	Express/Savana	Chassis	VSES																																																									
G	2006	Express/Savana	Body	Body Control Module																														V																												
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2006	Express/Savana	Body	Passenger Presence System																																																									
G	2006	Express/Savana	Body	Base Radio																																																									
G	2006	Express/Savana	Body	Uplevel Radio																																																									
G	2006	Express/Savana	Body	Remote Function Actuation																																																									
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																	V																									
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2006	Express Access/Savana Pro	Chassis	VSES																																																									
G	2006	Express Access/Savana Pro	Body	Body Control Module																														V																												
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2006	Express Access/Savana Pro	Body	Base Radio																																																									
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																	V																								
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2007	Express/Savana	Body	Body Control Module																														V																										
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2007	Express/Savana	Body	Passenger Presence System																																																								
G	2007	Express/Savana	Body	Base Radio																																																								
G	2007	Express/Savana	Body	Uplevel Radio																																																								
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																V																								
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																							
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2007	Express Access/Savana Pro	Body	Body Control Module																														V																										
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																							
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																							
G	2007	Express Access/Savana Pro	Body	Radio																																																							
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																							
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																V																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																							
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																							
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																							
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																							
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																							
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																							
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																							
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																							
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																							
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2008	Express/Savana	Body	Body Control Module																																																							
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2008	Express/Savana	Body	Passenger Presence System																																																							
G	2008	Express/Savana	Body	Radio																																																							
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
G	2008	Express/Savana	Body	Rollover Sensor																																																							
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																							
G	2008	Express/Savana	Body	Theft Deterrent Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																							
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2008	Express Access/Savana Pro	Body	Radio																																																										
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2009	Express/Savana	Body	Body Control Module																																																										
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2009	Express/Savana	Body	Passenger Presence System																																																										
G	2009	Express/Savana	Body	Radio																																																										
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express/Savana	Body	Rollover Sensor																																																										
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2009	Express/Savana	Body	Theft Deterrent Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2009	Express Access/Savana Pro	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express/Savana	Body	Body Control Module																																																												
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2010	Express/Savana	Body	Passenger Presence System																																																												
G	2010	Express/Savana	Body	Radio																																																											
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2010	Express/Savana	Body	Rollover Sensor																																																												
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2010	Express/Savana	Body	Theft Deterrent Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2010	Express Access/Savana Pro	Body	Radio																																																								
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2004	Express/Savana	Chassis	VSES																																																								
H	2004	Express/Savana	Body	Body Control Module																														V																										
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2004	Express/Savana	Body	OnStar																																V																								
H	2004	Express/Savana	Body	Base Radio																																																								
H	2004	Express/Savana	Body	Uplevel Radio																																																								
H	2004	Express/Savana	Body	Remote Function Actuation																																																								
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2004	Express Access/Savana Pro	Chassis	VSES																																																								
H	2004	Express Access/Savana Pro	Body	Body Control Module																														V																										
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2004	Express Access/Savana Pro	Body	OnStar																																V																								
H	2004	Express Access/Savana Pro	Body	Base Radio																																																								
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2005	Express/Savana	Chassis	VSES																																																								
H	2005	Express/Savana	Body	Body Control Module																														V																										
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2005	Express/Savana	Body	Base Radio																																																								
H	2005	Express/Savana	Body	Uplevel Radio																																																								
H	2005	Express/Savana	Body	Remote Function Actuation																																																								
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																V																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2005	Express Access/Savana Pro	Chassis	VSES																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2005	Express Access/Savana Pro	Body	Body Control Module																															V																											
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2005	Express Access/Savana Pro	Body	Base Radio																																																									
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																V																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2006	Express/Savana	Chassis	VSES																																																									
H	2006	Express/Savana	Body	Body Control Module																															V																											
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2006	Express/Savana	Body	Passenger Presence System																																																									
H	2006	Express/Savana	Body	Base Radio																																																									
H	2006	Express/Savana	Body	Uplevel Radio																																																									
H	2006	Express/Savana	Body	Remote Function Actuation																																																									
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																V																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
H	2006	Express Access/Savana Pro	Chassis	VSES																																																									
H	2006	Express Access/Savana Pro	Body	Body Control Module																															V																											
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2006	Express Access/Savana Pro	Body	Base Radio																																																									
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																V																									
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2007	Express/Savana	Body	Body Control Module																															V																											
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2007	Express/Savana	Body	Passenger Presence System																																																									
H	2007	Express/Savana	Body	Base Radio																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2007	Express/Savana	Body	Uplevel Radio																																																									
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																V																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express Access/Savana Pro	Body	Body Control Module																														V																													
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2007	Express Access/Savana Pro	Body	Base Radio																																																										
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																V																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express/Savana	Body	Body Control Module																																																										
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2008	Express/Savana	Body	Passenger Presence System																																																										
H	2008	Express/Savana	Body	Radio																																																										
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express/Savana	Body	Rollover Sensor																																																										
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express/Savana	Body	Theft Deterrent Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module																																																										
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																																										
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express/Savana	Body	Theft Deterrent Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express/Savana	Body	Body Control Module																																																										
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2010	Express/Savana	Body	Passenger Presence System																																																										
H	2010	Express/Savana	Body	Radio																																																										
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express/Savana	Body	Rollover Sensor																																																										
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express/Savana	Body	Theft Deterrent Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2010	Express Access/Savana Pro	Body	Radio																																																										
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																													
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																													
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																													
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																													
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																													
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																													
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																													
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																													
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																													
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																													
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																													
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																													
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																													
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																													
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																													
K	2004	ALL	Chassis	ESC																																																												
K	2004	ALL	Chassis	Rear Wheel Steering																																																													
K	2004	ALL	Chassis	Tire Pressure Monitor																																																												
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																												
K	2004	ALL	Chassis	VSES																																																												
K	2004	ALL	Body	Amplifier (Bose)																																																												
K	2004	ALL	Body	Body Control Module																														V																														
K	2004	ALL	Body	CD Changer																																																											
K	2004	ALL	Body	Chime																																																											
K	2004	ALL	Body	Driver Door Module																																																											
K	2004	ALL	Body	Driver Seat Module																																																											
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2004	ALL	Body	Instrument Panel Cluster																																																											
K	2004	ALL	Body	OnStar																																V																										
K	2004	ALL	Body	Passenger Door Module																																																										
K	2004	ALL	Body	Passenger Presence System																																																											
K	2004	ALL	Body	Radio Base																																																											
K	2004	ALL	Body	Radio Uplevel																																																											
K	2004	ALL	Body	Radio Navigation																																																											
K	2004	ALL	Body	Rear Aux. Climate Module																																																												
K	2004	ALL	Body	Rear HVAC																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2004	ALL	Body	Rear Seat Audio																																																									
K	2004	ALL	Body	Rear Seat Entertainment																																																									
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2004	ALL	Body	Vehicle Theft Deterrent																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																											
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
K	2005	ALL	Chassis	ESC																																																											
K	2005	ALL	Chassis	Rear Wheel Steering																																																											
K	2005	ALL	Chassis	Tire Pressure Monitor																																																											
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																											
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																											
K	2005	ALL	Body	Body Control Module																														V																													
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																											
K	2005	ALL	Body	Rear HVAC																																																											
K	2005	ALL	Body	Rear Seat Audio																																																											
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2005	ALL	Body	Vehicle Comm. Interface Module																																V																												
K	2005	ALL	Body	Vehicle Theft Deterrent																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																													
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																													
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																													
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																													
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																													
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																													
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																													
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																													
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																													
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																													
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																													
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																													
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																													
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																													
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																													
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																													
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																													
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																													
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																													
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																													
K	2006	ALL	Chassis	ESC																																																												
K	2006	ALL	Chassis	Tire Pressure Monitor																																																												
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																												
K	2006	ALL	Chassis	VSES																																																												
K	2006	ALL	Body	Amplifier (Bose)																																																												
K	2006	ALL	Body	Body Control Module																														V																														
K	2006	ALL	Body	CD Changer																																																											
K	2006	ALL	Body	Chime																																																											
K	2006	ALL	Body	Disc Player and Video Display																																																												
K	2006	ALL	Body	Driver Door Module																																																												
K	2006	ALL	Body	Driver Seat Module																																																												
K	2006	ALL	Body	Generator Battery Control Module																																																												
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2006	ALL	Body	Instrument Panel Cluster																																																								
K	2006	ALL	Body	Passenger Door Module																																																								
K	2006	ALL	Body	Passenger Presence System																																																								
K	2006	ALL	Body	Base Radio																																																								
K	2006	ALL	Body	Uplevel Radio																																																								
K	2006	ALL	Body	Navigation Radio																																																								
K	2006	ALL	Body	Rear Aux. Climate Module																																																								
K	2006	ALL	Body	Rear HVAC																																																								
K	2006	ALL	Body	Rear Seat Audio																																																								
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2006	ALL	Body	Vehicle Theft Deterrent																																																								
K	2006	ALL	Body	Vehicle Comm. Interface Module																																	V																							
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																								
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Sierra	Chassis	Electronic Suspension Control																																																									
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																									
K	2007	Sierra	Body	Amplifier (Bose)																																																									
K	2007	Sierra	Body	Body Control Module																																																									
K	2007	Sierra	Body	Body Control Module (aux.)																																																									
K	2007	Sierra	Body	Digital Radio Receiver																																																									
K	2007	Sierra	Body	Driver Door Switch																																																									
K	2007	Sierra	Body	HVAC Control Module Auto																																												V													
K	2007	Sierra	Body	HVAC Control Module Manual																																												V													
K	2007	Sierra	Body	Instrument Panel Cluster																																																									
K	2007	Sierra	Body	Memory Seat Module																																																									
K	2007	Sierra	Body	Park Assist Module																																																									
K	2007	Sierra	Body	Passenger Door Switch																																																									
K	2007	Sierra	Body	Passenger Presence System																																																									
K	2007	Sierra	Body	Radio																																																									
K	2007	Sierra	Body	Rear Heated Seat Module																																																									
K	2007	Sierra	Body	Rear HVAC/RSA																																																									
K	2007	Sierra	Body	Rollover Sensor																																																									
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																																									
K	2007	Sierra	Body	Theft Deterrent Module																																																									
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																									
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Yukon	Chassis	Electronic Suspension Control																																																									
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																									
K	2007	Yukon	Body	Amplifier (Bose)																																																									
K	2007	Yukon	Body	Assist Step Controller																																																									
K	2007	Yukon	Body	Body Control Module																																																									
K	2007	Yukon	Body	Body Control Module (aux.)																																																									
K	2007	Yukon	Body	Digital Radio Receiver																																																									
K	2007	Yukon	Body	Driver Door Switch																																																									
K	2007	Yukon	Body	HVAC Control Module Auto																																												V													
K	2007	Yukon	Body	HVAC Control Module Manual																																												V													
K	2007	Yukon	Body	Instrument Panel Cluster																																																									
K	2007	Yukon	Body	Lift Gate Module																																																									
K	2007	Yukon	Body	Memory Seat Module																																																									
K	2007	Yukon	Body	Park Assist Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2007	Yukon	Body	Passenger Door Switch																																																									
K	2007	Yukon	Body	Passenger Presence System																																																									
K	2007	Yukon	Body	Radio																																																									
K	2007	Yukon	Body	Rear Heated Seat Module																																																									
K	2007	Yukon	Body	Rear HVAC/RSA																																																									
K	2007	Yukon	Body	Rollover Sensor																																																									
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																																									
K	2007	Yukon	Body	Theft Deterrent Module																																																									
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																									
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																									
K	2007	Yukon XL	Body	Amplifier (Bose)																																																									
K	2007	Yukon XL	Body	Assist Step Controller																																																									
K	2007	Yukon XL	Body	Body Control Module																																																									
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																									
K	2007	Yukon XL	Body	Digital Radio Receiver																																																									
K	2007	Yukon XL	Body	Driver Door Switch																																																									
K	2007	Yukon XL	Body	HVAC Control Module Auto																																												V													
K	2007	Yukon XL	Body	HVAC Control Module Manual																																												V													
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																									
K	2007	Yukon XL	Body	Lift Gate Module																																																									
K	2007	Yukon XL	Body	Memory Seat Module																																																									
K	2007	Yukon XL	Body	Park Assist Module																																																									
K	2007	Yukon XL	Body	Passenger Door Switch																																																									
K	2007	Yukon XL	Body	Passenger Presence System																																																									
K	2007	Yukon XL	Body	Radio																																																									
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																									
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																									
K	2007	Yukon XL	Body	Rollover Sensor																																																									
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
K	2007	Yukon XL	Body	Theft Deterrent Module																																																									
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Sierra	Chassis	Electronic Suspension Control																																																										
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2008	Sierra	Body	Amplifier (Bose)																																																										
K	2008	Sierra	Body	Body Control Module																																																										
K	2008	Sierra	Body	Body Control Module (aux.)																																																										
K	2008	Sierra	Body	Digital Radio Receiver																																																										
K	2008	Sierra	Body	Driver Door Switch																																																										
K	2008	Sierra	Body	HVAC Control Module Auto																																												V														
K	2008	Sierra	Body	HVAC Control Module Manual																																												V														
K	2008	Sierra	Body	Instrument Panel Cluster																																																										
K	2008	Sierra	Body	Memory Seat Module																																																										
K	2008	Sierra	Body	Park Assist Module																																																										
K	2008	Sierra	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2008	Sierra	Body	Passenger Presence System																																																											
K	2008	Sierra	Body	Radio																																																											
K	2008	Sierra	Body	Rear Heated Seat Module																																																											
K	2008	Sierra	Body	Rear HVAC/RSA																																																											
K	2008	Sierra	Body	Rollover Sensor																																																											
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																																											
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																											
K	2008	Sierra	Body	Theft Deterrent Module																																																											
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Yukon	Chassis	Electronic Brake Control Module																																																											
K	2008	Yukon	Chassis	Electronic Suspension Control																																																											
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																											
K	2008	Yukon	Body	Amplifier (Bose)																																																											
K	2008	Yukon	Body	Assist Step Controller																																																											
K	2008	Yukon	Body	Body Control Module																																																											
K	2008	Yukon	Body	Body Control Module (aux.)																																																											
K	2008	Yukon	Body	Digital Radio Receiver																																																											
K	2008	Yukon	Body	Driver Door Switch																																																											
K	2008	Yukon	Body	HVAC Control Module Auto																																												V															
K	2008	Yukon	Body	HVAC Control Module Manual																																												V															
K	2008	Yukon	Body	Instrument Panel Cluster																																																											
K	2008	Yukon	Body	Lift Gate Module																																																											
K	2008	Yukon	Body	Memory Seat Module																																																											
K	2008	Yukon	Body	Park Assist Module																																																											
K	2008	Yukon	Body	Passenger Door Switch																																																											
K	2008	Yukon	Body	Passenger Presence System																																																											
K	2008	Yukon	Body	Radio																																																											
K	2008	Yukon	Body	Rear Heated Seat Module																																																											
K	2008	Yukon	Body	Rear HVAC/RSA																																																											
K	2008	Yukon	Body	Rollover Sensor																																																											
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																																											
K	2008	Yukon	Body	Theft Deterrent Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																									
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																									
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																									
K	2008	Yukon Hybrid	Body	Body Control Module																																																									
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																									
K	2008	Yukon Hybrid	Body	Driver Door Switch																																																									
K	2008	Yukon Hybrid	Body	HVAC Control Module																																												V													
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
K	2008	Yukon Hybrid	Body	Lift Gate Module																																																									
K	2008	Yukon Hybrid	Body	Memory Seat Module																																																									
K	2008	Yukon Hybrid	Body	Park Assist Module																																																									
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																																									
K	2008	Yukon Hybrid	Body	Passenger Presence System																																																									
K	2008	Yukon Hybrid	Body	Radio																																																									
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																									
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																									
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																									
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2008	Yukon XL	Body	Amplifier (Bose)																																																										
K	2008	Yukon XL	Body	Assist Step Controller																																																										
K	2008	Yukon XL	Body	Body Control Module																																																										
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2008	Yukon XL	Body	Digital Radio Receiver																																																										
K	2008	Yukon XL	Body	Driver Door Switch																																																										
K	2008	Yukon XL	Body	HVAC Control Module Auto																																																										
K	2008	Yukon XL	Body	HVAC Control Module Manual																																																										
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2008	Yukon XL	Body	Lift Gate Module																																																										
K	2008	Yukon XL	Body	Memory Seat Module																																																										
K	2008	Yukon XL	Body	Park Assist Module																																																										
K	2008	Yukon XL	Body	Passenger Door Switch																																																										
K	2008	Yukon XL	Body	Passenger Presence System																																																										
K	2008	Yukon XL	Body	Radio																																																										
K	2008	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2008	Yukon XL	Body	Rollover Sensor																																																										
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2008	Yukon XL	Body	Theft Deterrent Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2009	Sierra	Chassis	Electronic Suspension Control																																																												
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																												
K	2009	Sierra	Body	Amplifier (Bose)																																																												
K	2009	Sierra	Body	Body Control Module																																																												
K	2009	Sierra	Body	Body Control Module (aux.)																																																												
K	2009	Sierra	Body	Digital Radio Receiver																																																												
K	2009	Sierra	Body	Driver Door Switch																																																												
K	2009	Sierra	Body	HVAC Control Module Auto																																													V															
K	2009	Sierra	Body	HVAC Control Module Manual																																													V															
K	2009	Sierra	Body	Instrument Panel Cluster																																																												
K	2009	Sierra	Body	Memory Seat Module																																																												
K	2009	Sierra	Body	Park Assist Module																																																												
K	2009	Sierra	Body	Passenger Door Switch																																																												
K	2009	Sierra	Body	Passenger Presence System																																																												
K	2009	Sierra	Body	Radio																																																											
K	2009	Sierra	Body	Rear Heated Seat Module																																																												
K	2009	Sierra	Body	Rear HVAC/RSA																																																												
K	2009	Sierra	Body	Rollover Sensor																																																												
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																																												
K	2009	Sierra	Body	Theft Deterrent Module																																																												
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																											
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																									
K	2009	Sierra Hybrid	Body	Body Control Module																																																										
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Sierra Hybrid	Body	Driver Door Switch																																																										
K	2009	Sierra Hybrid	Body	HVAC Control Module																																												V														
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Sierra Hybrid	Body	Memory Seat Module																																																										
K	2009	Sierra Hybrid	Body	Park Assist Module																																																										
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																																										
K	2009	Sierra Hybrid	Body	Passenger Presence System																																																										
K	2009	Sierra Hybrid	Body	Radio																																																										
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Sierra Hybrid	Body	Rollover Sensor																																																										
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Yukon	Chassis	Electronic Brake Control Module																																																										
K	2009	Yukon	Chassis	Electronic Suspension Control																																																										
K	2009	Yukon	Chassis	Trailer Brake Control Module																																																										
K	2009	Yukon	Body	Amplifier (Bose)																																																										
K	2009	Yukon	Body	Assist Step Controller																																																										
K	2009	Yukon	Body	Body Control Module																																																										
K	2009	Yukon	Body	Body Control Module (aux.)																																																										
K	2009	Yukon	Body	Digital Radio Receiver																																																										
K	2009	Yukon	Body	Driver Door Switch																																																										
K	2009	Yukon	Body	HVAC Control Module Auto																																												V														
K	2009	Yukon	Body	HVAC Control Module Manual																																												V														

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2009	Yukon	Body	Instrument Panel Cluster																																																												
K	2009	Yukon	Body	Left Side Object Detection Module																																																												
K	2009	Yukon	Body	Lift Gate Module																																																												
K	2009	Yukon	Body	Memory Seat Module																																																												
K	2009	Yukon	Body	Park Assist Module																																																												
K	2009	Yukon	Body	Passenger Door Switch																																																												
K	2009	Yukon	Body	Passenger Presence System																																																												
K	2009	Yukon	Body	Radio																																																											
K	2009	Yukon	Body	Rear Heated Seat Module																																																												
K	2009	Yukon	Body	Rear HVAC/RSA																																																												
K	2009	Yukon	Body	Right Side Object Detection Module																																																												
K	2009	Yukon	Body	Rollover Sensor																																																												
K	2009	Yukon	Body	Supplemental Inflatable Restraint																																																												
K	2009	Yukon	Body	Theft Deterrent Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																												
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																												
K	2009	Yukon Hybrid	Body	Body Control Module																																																												
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Yukon Hybrid	Body	Driver Door Switch																																																												
K	2009	Yukon Hybrid	Body	Heated Seat Module																																																												
K	2009	Yukon Hybrid	Body	HVAC Control Module																																												V																
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
K	2009	Yukon Hybrid	Body	Park Assist Module																																																												
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																																												
K	2009	Yukon Hybrid	Body	Passenger Presence System																																																												
K	2009	Yukon Hybrid	Body	Radio																																																												
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
K	2009	Yukon Hybrid	Body	Rollover Sensor																																																												
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																												
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2009	Yukon XL	Body	Amplifier (Bose)																																																										
K	2009	Yukon XL	Body	Assist Step Controller																																																										
K	2009	Yukon XL	Body	Body Control Module																																																										
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2009	Yukon XL	Body	Digital Radio Receiver																																																										
K	2009	Yukon XL	Body	Driver Door Switch																																																										
K	2009	Yukon XL	Body	HVAC Control Module Auto																																												V														
K	2009	Yukon XL	Body	HVAC Control Module Manual																																												V														
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2009	Yukon XL	Body	Left Side Object Detection Module																																																										
K	2009	Yukon XL	Body	Lift Gate Module																																																										
K	2009	Yukon XL	Body	Memory Seat Module																																																										
K	2009	Yukon XL	Body	Park Assist Module																																																										
K	2009	Yukon XL	Body	Passenger Door Switch																																																										
K	2009	Yukon XL	Body	Passenger Presence System																																																										
K	2009	Yukon XL	Body	Radio																																																										
K	2009	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2009	Yukon XL	Body	Right Side Object Detection Module																																																										
K	2009	Yukon XL	Body	Rollover Sensor																																																										
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2009	Yukon XL	Body	Theft Deterrent Module																																																										
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																										
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2010	Sierra	Chassis	Electronic Suspension Control																																																												
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																												
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra	Body	Amplifier (Bose)																																																												
K	2010	Sierra	Body	Body Control Module																																																											
K	2010	Sierra	Body	Body Control Module (aux.)																																																											
K	2010	Sierra	Body	Digital Radio Receiver																																																											
K	2010	Sierra	Body	Driver Door Switch																																																											
K	2010	Sierra	Body	HVAC Control Module Auto																																												V															
K	2010	Sierra	Body	HVAC Control Module Manual																																												V															
K	2010	Sierra	Body	Instrument Panel Cluster																																																											
K	2010	Sierra	Body	Memory Seat Module																																																											
K	2010	Sierra	Body	Park Assist Module																																																											
K	2010	Sierra	Body	Passenger Door Switch																																																											
K	2010	Sierra	Body	Passenger Presence System																																																											
K	2010	Sierra	Body	Radio																																																											
K	2010	Sierra	Body	Rear Heated Seat Module																																																											
K	2010	Sierra	Body	Rear HVAC/RSA																																																											
K	2010	Sierra	Body	Supplemental Inflatable Restraint																									V	V																																	
K	2010	Sierra	Body	Theft Deterrent Module																																																											
K	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																											
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																									
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Sierra Hybrid	Body	Body Control Module																																																										
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Sierra Hybrid	Body	Driver Door Switch																																																										
K	2010	Sierra Hybrid	Body	Heated Seat Module																																																										
K	2010	Sierra Hybrid	Body	HVAC Control Module																																												V															
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Sierra Hybrid	Body	Park Assist Module																																																										
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																																										
K	2010	Sierra Hybrid	Body	Passenger Presence System																																																										
K	2010	Sierra Hybrid	Body	Radio																																																										
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon	Chassis	Electronic Brake Control Module																																																										
K	2010	Yukon	Chassis	Electronic Suspension Control																																																										
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon	Body	Amplifier (Bose)																																																										
K	2010	Yukon	Body	Assist Step Controller																																																										
K	2010	Yukon	Body	Body Control Module																																																										
K	2010	Yukon	Body	Body Control Module (aux.)																																																										
K	2010	Yukon	Body	Digital Radio Receiver																																																										
K	2010	Yukon	Body	Driver Door Switch																																																										
K	2010	Yukon	Body	HVAC Control Module Auto																																												V															
K	2010	Yukon	Body	HVAC Control Module Manual																																												V															

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2010	Yukon	Body	Instrument Panel Cluster																																																									
K	2010	Yukon	Body	Left Side Object Detection Module																																																										
K	2010	Yukon	Body	Lift Gate Module																																																										
K	2010	Yukon	Body	Memory Seat Module																																																										
K	2010	Yukon	Body	Park Assist Module																																																										
K	2010	Yukon	Body	Passenger Door Switch																																																										
K	2010	Yukon	Body	Passenger Presence System																																																										
K	2010	Yukon	Body	Radio																																																										
K	2010	Yukon	Body	Rear Heated Seat Module																																																										
K	2010	Yukon	Body	Rear HVAC/RSA																																																										
K	2010	Yukon	Body	Right Side Object Detection Module																																																										
K	2010	Yukon	Body	Supplemental Inflatable Restraint																									V	V																																
K	2010	Yukon	Body	Theft Deterrent Module																																																										
K	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																										
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Yukon Hybrid	Body	Body Control Module																																																										
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Yukon Hybrid	Body	Driver Door Switch																																																										
K	2010	Yukon Hybrid	Body	Heated Seat Module																																																										
K	2010	Yukon Hybrid	Body	HVAC Control Module																																													V															
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
K	2010	Yukon Hybrid	Body	Lift Gate Module																																																										
K	2010	Yukon Hybrid	Body	Park Assist Module																																																										
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																																										
K	2010	Yukon Hybrid	Body	Passenger Presence System																																																										
K	2010	Yukon Hybrid	Body	Radio																																																										
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																										
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																										
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2010	Yukon XL	Body	Amplifier (Bose)																																																										
K	2010	Yukon XL	Body	Assist Step Controller																																																										
K	2010	Yukon XL	Body	Body Control Module																																																										
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2010	Yukon XL	Body	Digital Radio Receiver																																																										
K	2010	Yukon XL	Body	Driver Door Switch																																																										
K	2010	Yukon XL	Body	HVAC Control Module Auto																																												V														
K	2010	Yukon XL	Body	HVAC Control Module Manual																																												V														
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2010	Yukon XL	Body	Left Side Object Detection Module																																																										
K	2010	Yukon XL	Body	Lift Gate Module																																																										
K	2010	Yukon XL	Body	Memory Seat Module																																																										
K	2010	Yukon XL	Body	Park Assist Module																																																										
K	2010	Yukon XL	Body	Passenger Door Switch																																																										
K	2010	Yukon XL	Body	Passenger Presence System																																																										
K	2010	Yukon XL	Body	Radio																																																										
K	2010	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2010	Yukon XL	Body	Right Side Object Detection Module																																																										
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																									V	V																																
K	2010	Yukon XL	Body	Theft Deterrent Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2004	ALL	Chassis	4WAL 3 Sensor																																																										
L	2004	ALL	Body	Body Control Module																														V																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2004	ALL	Body	Instrument Panel Cluster																																																								
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
L	2005	ALL	Chassis	4WAL 3 Sensor																																																								
L	2005	ALL	Body	Body Control Module																															V																									
L	2005	ALL	Body	Instrument Panel Cluster																																																								
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																								
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																								
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																								
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																								
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																								
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																								
L	2010	Terrain	Chassis	Electronic Brake Control Module					V																																																			
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
L	2010	Terrain	Body	Body Control Module						V	V	V	V	V	V	V		V	V	V	V	V	V	V			V	V																																
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
L	2010	Terrain	Body	Passenger Presence Module																																V																								
L	2010	Terrain	Body	Instrument Cluster																																	V																							
L	2010	Terrain	Body	Radio																																																								
L	2010	Terrain	Body	Multimedia Player Interface Module																																	V																							
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																		V	V	V	V																			
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																															V												V	V	V	V	V									
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																															V												V	V	V	V	V									
L	2010	Terrain	Body	Liftgate Control Module																																																								
L	2010	Terrain	Body	Parking Assist Control Module																																V																								
L	2010	Terrain	Body	Frontview Camera Module																																																								
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																																								
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																				V																											V									
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																								
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																				
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																								
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																								
L	2011	Terrain	Chassis	Electronic Brake Control Module					V																																																			
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
L	2011	Terrain	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																								V								
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
L	2011	Terrain	Body	Passenger Presence Module																																V																								
L	2011	Terrain	Body	Instrument Cluster																																	V																							
L	2011	Terrain	Body	Radio																																																								
L	2011	Terrain	Body	Multimedia Player Interface Module																																	V																							
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																															V												V	V	V	V	V									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																															V												V	V	V	V	V								
L	2011	Terrain	Body	Liftgate Control Module																																																							
L	2011	Terrain	Body	Parking Assist Control Module																																V																							
L	2011	Terrain	Body	Frontview Camera Module																																																						
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																																						
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																				V																											V							
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																						
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																				V																																			
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																						
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																						
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																						
L	2012	Terrain	Chassis	Electronic Brake Control Module					V																																																	
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																						
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
L	2012	Terrain	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																								V						
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
L	2012	Terrain	Body	Passenger Presence Module																																V																							
L	2012	Terrain	Body	Instrument Cluster																																	V																						
L	2012	Terrain	Body	Radio																																																						
L	2012	Terrain	Body	Multimedia Player Interface Module																																	V																						
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																	
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																	
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V							
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V							
L	2012	Terrain	Body	Liftgate Control Module																																																						
L	2012	Terrain	Body	Parking Assist Control Module																																V																						
L	2012	Terrain	Body	Frontview Camera Module																																																						
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																																						
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																				V																											V							
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																						
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																			
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																						
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																						
L	2013	Terrain	Chassis	Electronic Brake Control Module					V																																																	
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																						
L	2013	Terrain	Chassis	Power Steering Control Module	V	V	V																																																			
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																								V						
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																								V						
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
L	2013	Terrain	Body	Passenger Presence Module																																V																							
L	2013	Terrain	Body	Instrument Cluster																																	V																						
L	2013	Terrain	Body	Radio																																																						
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																	
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																	
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V							
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V							
L	2013	Terrain	Body	Liftgate Control Module																																																						
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																						
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																						
L	2013	Terrain	Body	Parking Assist Control Module																																V																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2013	Terrain	Body	Frontview Camera Module																																																								
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																				V																											V								
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																							
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																							
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																							
L	2014	Terrain	Chassis	Electronic Brake Control Module					V																																																		
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																							
L	2014	Terrain	Chassis	Power Steering Control Module	V	V	V																																																					
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																									V						
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																									V						
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
L	2014	Terrain	Body	Passenger Presence Module																																V																								
L	2014	Terrain	Body	Instrument Cluster																																	V																						
L	2014	Terrain	Body	Radio																																																							
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																		
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V							
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V							
L	2014	Terrain	Body	Liftgate Control Module																																																						
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																						
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																						
L	2014	Terrain	Body	Parking Assist Control Module																																	V																						
L	2014	Terrain	Body	Frontview Camera Module																																																						
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																				V																											V								
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																							
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																							
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																							
L	2015	Terrain	Chassis	Electronic Brake Control Module					V																																																		
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																							
L	2015	Terrain	Chassis	Power Steering Control Module	V	V	V																																																				
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																									V						
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																									V						
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
L	2015	Terrain	Body	Passenger Presence Module																																V																						
L	2015	Terrain	Body	Instrument Cluster																																	V																						
L	2015	Terrain	Body	Radio																																																						
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																		V	V	V																		
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V							
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V							
L	2015	Terrain	Body	Liftgate Control Module																																																						
L	2015	Terrain	Body	Seat Memory Control Module																																																						
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																						
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																						
L	2015	Terrain	Body	Parking Assist Control Module																																	V																						
L	2015	Terrain	Body	Frontview Camera Module																																																						
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																				V																											V								
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																				
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																							
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																							
L	2016	Terrain	Chassis	Electronic Brake Control Module					V																																																		
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																							
L	2016	Terrain	Chassis	Power Steering Control Module	V	V	V																																																				
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																								V						
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)						V	V	V	V	V	V	V		V	V		V	V	V	V			V	V																								V						
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
L	2016	Terrain	Body	Passenger Presence Module																																V																							
L	2016	Terrain	Body	Instrument Cluster																																	V																						
L	2016	Terrain	Body	Radio																																																							
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																		V	V	V																		
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																		
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V	V							
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V	V							
L	2016	Terrain	Body	Liftgate Control Module																																																						
L	2016	Terrain	Body	Seat Memory Control Module																																																						
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																						
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																						
L	2016	Terrain	Body	Parking Assist Control Module																																V																							
L	2016	Terrain	Body	Frontview Camera Module																																																						
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																						
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
M	2004	ALL	Chassis	4WAL 3 Sensor																																																						
M	2004	ALL	Body	Body Control Module																														V																							
M	2004	ALL	Body	Instrument Panel Cluster																																																						
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																						
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																						
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
M	2005	ALL	Chassis	4WAL 3 Sensor																																																						
M	2005	ALL	Body	Body Control Module																														V																							
M	2005	ALL	Body	Instrument Panel Cluster																																																						
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																						
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																						
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																						
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																						
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																						
P	2007	ALL	Body	Theft Deterrent Module																																																						
R	2007	ALL	Powertrain	Engine Control Module																																																						
R	2007	ALL	Powertrain	Transmission Control Module																																																						
R	2007	ALL	Chassis	Electronic Brake Control Module																																																						
R	2007	ALL	Body	Body Control Module																																																						
R	2007	ALL	Body	Digital Radio Receiver																																																						
R	2007	ALL	Body	Driver Door Switch																																																						
R	2007	ALL	Body	Head Up Display																																																						
R	2007	ALL	Body	Heated Seat Module																																																						
R	2007	ALL	Body	HVAC Control Module Auto																																											V											
R	2007	ALL	Body	HVAC Control Module Manual																																											V											
R	2007	ALL	Body	Instrument Panel Cluster																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2007	ALL	Body	Lift Gate Module																																																									
R	2007	ALL	Body	Park Assist Module																																																									
R	2007	ALL	Body	Passenger Door Switch																																																									
R	2007	ALL	Body	Passenger Presence System																																																									
R	2007	ALL	Body	Radio																																																									
R	2007	ALL	Body	Rear HVAC/RSA																																																									
R	2007	ALL	Body	Rollover Sensor																																																									
R	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2007	ALL	Body	Theft Deterrent Module																																																										
R	2008	ALL	Powertrain	Engine Control Module																																																										
R	2008	ALL	Powertrain	Transmission Control Module																																																										
R	2008	ALL	Chassis	Electronic Brake Control Module																																																										
R	2008	ALL	Body	Body Control Module																																																										
R	2008	ALL	Body	Digital Radio Receiver																																																										
R	2008	ALL	Body	Driver Door Switch																																																										
R	2008	ALL	Body	Head Up Display																																																										
R	2008	ALL	Body	Heated Seat Module																																																										
R	2008	ALL	Body	HVAC Control Module Auto																																												V														
R	2008	ALL	Body	HVAC Control Module Manual																																												V														
R	2008	ALL	Body	Instrument Panel Cluster																																																										
R	2008	ALL	Body	Lift Gate Module																																																										
R	2008	ALL	Body	Park Assist Module																																																										
R	2008	ALL	Body	Passenger Door Switch																																																										
R	2008	ALL	Body	Passenger Presence System																																																										
R	2008	ALL	Body	Radio																																																										
R	2008	ALL	Body	Rear HVAC/RSA																																																										
R	2008	ALL	Body	Rollover Sensor																																																										
R	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2008	ALL	Body	Theft Deterrent Module																																																										
R	2009	ALL	Powertrain	Engine Control Module																																																										
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2009	ALL	Powertrain	Transmission Control Module																																																										
R	2009	ALL	Chassis	Electronic Brake Control Module																																																										
R	2009	ALL	Body	Body Control Module																																																										
R	2009	ALL	Body	Digital Radio Receiver																																																										
R	2009	ALL	Body	Driver Door Switch																																																										
R	2009	ALL	Body	Head Up Display																																																										
R	2009	ALL	Body	Heated Seat Module																																																										
R	2009	ALL	Body	HVAC Control Module Auto																																												V														
R	2009	ALL	Body	HVAC Control Module Manual																																												V														
R	2009	ALL	Body	Instrument Panel Cluster																																																										
R	2009	ALL	Body	Lift Gate Module																																																										
R	2009	ALL	Body	Park Assist Module																																																										
R	2009	ALL	Body	Passenger Door Switch																																																										
R	2009	ALL	Body	Passenger Presence System																																																										
R	2009	ALL	Body	Radio																																																										
R	2009	ALL	Body	Rear HVAC/RSA																																																										
R	2009	ALL	Body	Rollover Sensor																																																										
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2009	ALL	Body	Theft Deterrent Module																																																										
R	2010	ALL	Powertrain	Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2010	ALL	Powertrain	Transmission Control Module																																																										
R	2010	ALL	Chassis	Electronic Brake Control Module																																																										
R	2010	ALL	Body	Body Control Module																																																										
R	2010	ALL	Body	Digital Radio Receiver																																																										
R	2010	ALL	Body	Driver Door Switch																																																										
R	2010	ALL	Body	Head Up Display																																																										
R	2010	ALL	Body	Heated Seat Module																																																										
R	2010	ALL	Body	HVAC Control Module Auto																																												V														
R	2010	ALL	Body	HVAC Control Module Manual																																												V														
R	2010	ALL	Body	Instrument Panel Cluster																																																										
R	2010	ALL	Body	Lift Gate Module																																																										
R	2010	ALL	Body	Park Assist Module																																																										
R	2010	ALL	Body	Passenger Door Switch																																																										
R	2010	ALL	Body	Passenger Presence System																																																										
R	2010	ALL	Body	Radio																																																										
R	2010	ALL	Body	Rear HVAC/RSA																																																										
R	2010	ALL	Body	Supplemental Inflatable Restraint																									V	V																																
R	2010	ALL	Body	Theft Deterrent Module																																																										
R	2011	ALL	Powertrain	Engine Control Module																																																										
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2011	ALL	Powertrain	Transmission Control Module																																																										
R	2011	ALL	Chassis	Electronic Brake Control Module																																																										
R	2011	ALL	Body	Body Control Module																																																										
R	2011	ALL	Body	Digital Radio Receiver																																																										
R	2011	ALL	Body	Driver Door Switch																																																										
R	2011	ALL	Body	Head Up Display																																																										
R	2011	ALL	Body	Heated Seat Module																																																										
R	2011	ALL	Body	HVAC Control Module Auto																																												V														
R	2011	ALL	Body	HVAC Control Module Manual																																												V														
R	2011	ALL	Body	Instrument Panel Cluster																																																										
R	2011	ALL	Body	Lift Gate Module																																																										
R	2011	ALL	Body	Park Assist Module																																																										
R	2011	ALL	Body	Passenger Door Switch																																																										
R	2011	ALL	Body	Passenger Presence System																																																										
R	2011	ALL	Body	Radio																																																										
R	2011	ALL	Body	Rear HVAC/RSA																																																										
R	2011	ALL	Body	Supplemental Inflatable Restraint																									V	V																																
R	2011	ALL	Body	Theft Deterrent Module																																																										
R	2012	ALL	Powertrain	Engine Control Module																				V																																							
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2012	ALL	Powertrain	Transmission Control Module																																																										
R	2012	ALL	Chassis	Electronic Brake Control Module																																																										
R	2012	ALL	Body	Body Control Module																																																										
R	2012	ALL	Body	Digital Radio Receiver																																																										
R	2012	ALL	Body	Driver Door Switch																																																										
R	2012	ALL	Body	Head Up Display																																																										
R	2012	ALL	Body	Heated Seat Module																																																										
R	2012	ALL	Body	HVAC Control Module Auto																																												V														
R	2012	ALL	Body	HVAC Control Module Manual																																												V														
R	2012	ALL	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2012	ALL	Body	Lift Gate Module																																																									
R	2012	ALL	Body	Park Assist Module																																																									
R	2012	ALL	Body	Passenger Door Switch																																																									
R	2012	ALL	Body	Passenger Presence System																																																									
R	2012	ALL	Body	Radio																																																									
R	2012	ALL	Body	Rear HVAC/RSA																																																									
R	2012	ALL	Body	Supplemental Inflatable Restraint																								V	V																																
R	2012	ALL	Body	Theft Deterrent Module																																																									
R	2013	ALL	Powertrain	Engine Control Module																				V																																						
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2013	ALL	Powertrain	Transmission Control Module																																																										
R	2013	ALL	Chassis	Electronic Brake Control Module																																																										
R	2013	ALL	Body	Body Control Module																																																										
R	2013	ALL	Body	Digital Radio Receiver																																																										
R	2013	ALL	Body	Driver Door Switch																																																										
R	2013	ALL	Body	Head Up Display																																																										
R	2013	ALL	Body	Heated Seat Module																																																										
R	2013	ALL	Body	HVAC Control Module Auto																																													V														
R	2013	ALL	Body	HVAC Control Module Manual																																													V														
R	2013	ALL	Body	Instrument Panel Cluster																																																										
R	2013	ALL	Body	Left Side Object Detection Module																																																										
R	2013	ALL	Body	Lift Gate Module																																																										
R	2013	ALL	Body	Park Assist Module																																																										
R	2013	ALL	Body	Passenger Door Switch																																																										
R	2013	ALL	Body	Passenger Presence System																																																										
R	2013	ALL	Body	Radio																																																										
R	2013	ALL	Body	Rear HVAC/RSA																																																										
R	2013	ALL	Body	Right Side Object Detection Module																																																										
R	2013	ALL	Body	Supplemental Inflatable Restraint																								V	V																																	
R	2013	ALL	Body	Theft Deterrent Module																																																										
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																						
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2014	Acadia	Powertrain	Chassis Control Module																																																										
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
R	2014	Acadia	Chassis	Electronic Brake Control Module					V																																																					
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate						V	V	V						V				V	V	V																																						
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)						V	V	V						V				V	V	V																																						
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V																													
R	2014	Acadia	Body	Passenger Presence Module																									V						V																											
R	2014	Acadia	Body	Instrument Cluster																																																										
R	2014	Acadia	Body	Head-Up Display Module																																																										
R	2014	Acadia	Body	Radio																																																										
R	2014	Acadia	Body	Rear Audio Control Module																																																										
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																										
R	2014	Acadia	Body	Personal Audio Link Control Module																																																										
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																					
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																									V	V		V	V									
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																									V	V		V	V									
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																	V																																								
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2014	Acadia	Body	Liftgate Control Module																																																								
R	2014	Acadia	Body	Seat Memory Control Module																																					V	V																		
R	2014	Acadia	Body	Front Seat Heating Control Module																																					V	V																		
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																							
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																							
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																							
R	2014	Acadia	Body	Parking Assist Control Module																																V																							
R	2014	Acadia	Body	Frontview Camera Module																																																							
R	2014	Acadia	Body	Theft Deterrent Module										V																																													
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																			
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																							
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																							
R	2015	Acadia	Chassis	Electronic Brake Control Module					V																																																		
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate						V	V	V						V				V	V	V																																			
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)						V	V	V						V				V	V	V																																			
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																								
R	2015	Acadia	Body	Passenger Presence Module																										V						V																							
R	2015	Acadia	Body	Instrument Cluster																																																						
R	2015	Acadia	Body	Head-Up Display Module																																																						
R	2015	Acadia	Body	Radio																																																						
R	2015	Acadia	Body	Rear Audio Control Module																																																						
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																						
R	2015	Acadia	Body	Personal Audio Link Control Module																																																						
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																		
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																										V	V		V	V								
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																										V	V		V	V								
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																	V																																						
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																						
R	2015	Acadia	Body	Liftgate Control Module																																																						
R	2015	Acadia	Body	Seat Memory Control Module																																					V	V																	
R	2015	Acadia	Body	Front Seat Heating Control Module																																					V	V																	
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																						
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																						
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																						
R	2015	Acadia	Body	Parking Assist Control Module																																V																							
R	2015	Acadia	Body	Frontview Camera Module																																																						
R	2015	Acadia	Body	Theft Deterrent Module										V																																												
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																			
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																						
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																						
R	2016	Acadia	Chassis	Electronic Brake Control Module					V																																																	
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate						V	V	V						V				V	V	V																																			
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)						V	V	V						V				V	V	V																																			
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																								
R	2016	Acadia	Body	Passenger Presence Module																										V						V																							
R	2016	Acadia	Body	Instrument Cluster																																																						
R	2016	Acadia	Body	Head-Up Display Module																																																						
R	2016	Acadia	Body	Radio																																																						
R	2016	Acadia	Body	Rear Audio Control Module																																																						
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
R	2016	Acadia	Body	Personal Audio Link Control Module																																																								
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																V	V	V																				
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																								V	V		V	V									
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																								V	V		V	V									
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																	V																																						
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																							
R	2016	Acadia	Body	Liftgate Control Module																																																							
R	2016	Acadia	Body	Seat Memory Control Module																																				V	V																		
R	2016	Acadia	Body	Front Seat Heating Control Module																																				V	V																		
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																							
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																							
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																							
R	2016	Acadia	Body	Parking Assist Control Module																																V																							
R	2016	Acadia	Body	Frontview Camera Module																																																							
R	2016	Acadia	Body	Theft Deterrent Module										V																																													
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																							
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																						
S	2004	Sonoma	Body	Body Control Module																														V																								
S	2004	Sonoma	Body	Instrument Panel Cluster																																																						
S	2004	Sonoma	Body	Base Radio																																																						
S	2004	Sonoma	Body	Uplevel Radio																																																						
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																						
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																						
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																						
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																						
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																						
S	2004	Canyon	Chassis	ABS Without Traction Control																																																						
S	2004	Canyon	Chassis	ABS With Traction Control																																																						
S	2004	Canyon	Body	Body Control Module																														V																								
S	2004	Canyon	Body	Instrument Panel Cluster																																																						
S	2004	Canyon	Body	OnStar																																V																							
S	2004	Canyon	Body	Base Radio																																																						
S	2004	Canyon	Body	Uplevel Radio																																																						
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																																						
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																						
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																						
S	2004	Envoy	Chassis	ABS Without Traction Control																																																						
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																						
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																						
S	2004	Envoy	Body	Amplifier (Bose)																																																						
S	2004	Envoy	Body	Body Control Module																																																						
S	2004	Envoy	Body	Driver Door Module																																																						
S	2004	Envoy	Body	Driver Seat Module																																																						
S	2004	Envoy	Body	Heating and Air Conditioning Auto																																																						
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																						
S	2004	Envoy	Body	Instrument Panel Cluster																																																						
S	2004	Envoy	Body	Lift Gate Module																																																						
S	2004	Envoy	Body	OnStar																																V																							
S	2004	Envoy	Body	Passenger Door Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2004	Envoy	Body	Uplevel Radio																																																									
S	2004	Envoy	Body	Navigation Radio																																																										
S	2004	Envoy	Body	Rear Seat Audio																																																										
S	2004	Envoy	Body	Rear Seat Entertainment																																																										
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy XL	Body	Amplifier (Bose)																																																										
S	2004	Envoy XL	Body	Body Control Module																																																										
S	2004	Envoy XL	Body	Driver Door Module																																																										
S	2004	Envoy XL	Body	Driver Seat Module																																																										
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																										
S	2004	Envoy XL	Body	Lift Gate Module																																																										
S	2004	Envoy XL	Body	OnStar																																	V																									
S	2004	Envoy XL	Body	Passenger Door Module																																																										
S	2004	Envoy XL	Body	Uplevel Radio																																																										
S	2004	Envoy XL	Body	Navigation Radio																																																										
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
S	2004	Envoy XL	Body	Rear HVAC Manual																																																										
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																										
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																										
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																										
S	2004	Envoy XUV	Body	Body Control Module																																																										
S	2004	Envoy XUV	Body	Driver Door Module																																																										
S	2004	Envoy XUV	Body	Driver Seat Module																																																										
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																										
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																										
S	2004	Envoy XUV	Body	Lift Gate Module																																																										
S	2004	Envoy XUV	Body	OnStar																																	V																									
S	2004	Envoy XUV	Body	Passenger Door Module																																																										
S	2004	Envoy XUV	Body	Uplevel Radio																																																										
S	2004	Envoy XUV	Body	Navigation Radio																																																										
S	2004	Envoy XUV	Body	Rear Seat Audio																																																										
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																								
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																								
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																								
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																								
S	2004	Jimmy	Body	Body Control Module																															V																									
S	2004	Jimmy	Body	Heating and Air Conditioning																																																								
S	2004	Jimmy	Body	Instrument Panel Cluster																																																								
S	2004	Jimmy	Body	Memory Seat Module																																																								
S	2004	Jimmy	Body	Base Radio																																																								
S	2004	Jimmy	Body	Uplevel Radio																																																								
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																								
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																								
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																								
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																								
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																								
S	2005	Canyon	Chassis	ABS Without Traction Control																																																								
S	2005	Canyon	Chassis	ABS With Traction Control																																																								
S	2005	Canyon	Body	Body Control Module																															V																									
S	2005	Canyon	Body	Instrument Panel Cluster																																																								
S	2005	Canyon	Body	Base Radio																																																								
S	2005	Canyon	Body	Uplevel Radio																																																								
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																																								
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																	V																							
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
S	2005	Envoy	Chassis	ABS Without Traction Control																																																								
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																								
S	2005	Envoy	Body	Body Control Module																																																								
S	2005	Envoy	Body	Disc Player and Video Display																																																								
S	2005	Envoy	Body	Driver Door Module																																																								
S	2005	Envoy	Body	Driver Seat Module																																																								
S	2005	Envoy	Body	Heating and Air Conditioning Auto																																																								
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																																								
S	2005	Envoy	Body	Instrument Panel Cluster																																																								
S	2005	Envoy	Body	Lift Gate Module																																																								
S	2005	Envoy	Body	Passenger Door Module																																																								
S	2005	Envoy	Body	Passenger Presence System																																																								
S	2005	Envoy	Body	Uplevel Radio																																																								
S	2005	Envoy	Body	Navigation Radio																																																								
S	2005	Envoy	Body	Rear Seat Audio																																																								
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																																								
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																	V																							
S	2005	Envoy	Body	Vehicle Theft Deterrent																																																								
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy XL	Body	Body Control Module																																																										
S	2005	Envoy XL	Body	Disc Player and Video Display																																																										
S	2005	Envoy XL	Body	Driver Door Module																																																										
S	2005	Envoy XL	Body	Driver Seat Module																																																										
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy XL	Body	Instrument Panel Cluster																																																										
S	2005	Envoy XL	Body	Lift Gate Module																																																										
S	2005	Envoy XL	Body	Passenger Door Module																																																										
S	2005	Envoy XL	Body	Passenger Presence System																																																										
S	2005	Envoy XL	Body	Uplevel Radio																																																										
S	2005	Envoy XL	Body	Navigation Radio																																																										
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
S	2005	Envoy XL	Body	Rear HVAC Manual																																																										
S	2005	Envoy XL	Body	Rear Seat Audio																																																										
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																V																										
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																										
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy XUV	Body	Body Control Module																																																										
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																										
S	2005	Envoy XUV	Body	Driver Door Module																																																										
S	2005	Envoy XUV	Body	Driver Seat Module																																																										
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																										
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																																										
S	2005	Envoy XUV	Body	Lift Gate Module																																																										
S	2005	Envoy XUV	Body	Passenger Door Module																																																										
S	2005	Envoy XUV	Body	Passenger Presence System																																																										
S	2005	Envoy XUV	Body	Uplevel Radio																																																										
S	2005	Envoy XUV	Body	Navigation Radio																																																										
S	2005	Envoy XUV	Body	Rear Seat Audio																																																										
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																V																										
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																										
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Jimmy	Body	Body Control Module																														V																										
S	2005	Jimmy	Body	Heating and Air Conditioning																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2005	Jimmy	Body	Instrument Panel Cluster																																																									
S	2005	Jimmy	Body	Memory Seat Module																																																									
S	2005	Jimmy	Body	Base Radio																																																								
S	2005	Jimmy	Body	Uplevel Radio																																																								
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																								
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																								
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																								
S	2005	Sonoma	Body	Body Control Module																														V																											
S	2005	Sonoma	Body	Instrument Panel Cluster																																																								
S	2005	Sonoma	Body	Base Radio																																																								
S	2005	Sonoma	Body	Uplevel Radio																																																								
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																								
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																								
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																								
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																								
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																								
S	2006	Canyon	Chassis	ABS Without Traction Control																																																								
S	2006	Canyon	Chassis	ABS With Traction Control																																																								
S	2006	Canyon	Body	Body Control Module																														V																											
S	2006	Canyon	Body	Instrument Panel Cluster																																																								
S	2006	Canyon	Body	Passenger Presence System																																																								
S	2006	Canyon	Body	Base Radio																																																								
S	2006	Canyon	Body	Uplevel Radio																																																								
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																																								
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																	V																								
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
S	2006	Envoy	Chassis	ABS/TCS/VSES																																																								
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																								
S	2006	Envoy	Body	Body Control Module																														V																											
S	2006	Envoy	Body	Disc Player and Video Display																																																								
S	2006	Envoy	Body	Driver Door Module																																																								
S	2006	Envoy	Body	Driver Seat Module																																																								
S	2006	Envoy	Body	Heating and Air Conditioning Auto																																																								
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																																								
S	2006	Envoy	Body	Instrument Panel Cluster																																																								
S	2006	Envoy	Body	Lift Gate Module																																																								
S	2006	Envoy	Body	Passenger Door Module																																																								
S	2006	Envoy	Body	Passenger Presence System																																																								
S	2006	Envoy	Body	Uplevel Radio																																																								
S	2006	Envoy	Body	Navigation Radio																																																								
S	2006	Envoy	Body	Rear Seat Audio																																																								
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																																								
S	2006	Envoy	Body	Vehicle Theft Deterrent																																																								
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																	V																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																								
S	2006	Envoy XL	Body	Body Control Module																															V																									
S	2006	Envoy XL	Body	Disc Player and Video Display																																																								
S	2006	Envoy XL	Body	Driver Door Module																																																								
S	2006	Envoy XL	Body	Driver Seat Module																																																								
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																								
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																								
S	2006	Envoy XL	Body	Instrument Panel Cluster																																																								
S	2006	Envoy XL	Body	Lift Gate Module																																																								
S	2006	Envoy XL	Body	Passenger Door Module																																																								
S	2006	Envoy XL	Body	Passenger Presence System																																																								
S	2006	Envoy XL	Body	Uplevel Radio																																																								
S	2006	Envoy XL	Body	Navigation Radio																																																								
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																								
S	2006	Envoy XL	Body	Rear HVAC Manual																																																								
S	2006	Envoy XL	Body	Rear Seat Audio																																																								
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																								
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																								
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																	V																							
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																								
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																								
S	2007	Canyon	Body	Body Control Module																															V																									
S	2007	Canyon	Body	Digital Radio Receiver																																																								
S	2007	Canyon	Body	Generator Battery Control Module																																																								
S	2007	Canyon	Body	Instrument Panel Cluster																																																								
S	2007	Canyon	Body	Passenger Presence System																																																								
S	2007	Canyon	Body	Base Radio																																																								
S	2007	Canyon	Body	Uplevel Radio																																																								
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																																								
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																	V																							
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																								
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																								
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
S	2007	Envoy	Chassis	Electronic Brake Control Module																																																								
S	2007	Envoy	Body	Body Control Module																															V																									
S	2007	Envoy	Body	Digital Radio Receiver																																																								
S	2007	Envoy	Body	Disc Player and Video Display																																																								
S	2007	Envoy	Body	Driver Door Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2007	Envoy	Body	Driver Seat Module																																																									
S	2007	Envoy	Body	Generator Battery Control Module																																																										
S	2007	Envoy	Body	HVAC Control Module Auto																																																										
S	2007	Envoy	Body	HVAC Control Module Manual																																																										
S	2007	Envoy	Body	Instrument Panel Cluster																																																										
S	2007	Envoy	Body	Lift Gate Module																																																										
S	2007	Envoy	Body	Passenger Door Module																																																										
S	2007	Envoy	Body	Passenger Presence System																																																										
S	2007	Envoy	Body	Uplevel Radio																																																										
S	2007	Envoy	Body	Navigation Radio																																																										
S	2007	Envoy	Body	Rear Seat Audio																																																										
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2007	Envoy	Body	Theft Deterrent Module																																																										
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																	V																										
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																										
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																										
S	2008	Canyon	Body	Body Control Module																														V																												
S	2008	Canyon	Body	Digital Radio Receiver																																																										
S	2008	Canyon	Body	Generator Battery Control Module																																																										
S	2008	Canyon	Body	Instrument Panel Cluster																																																										
S	2008	Canyon	Body	Passenger Presence System																																																										
S	2008	Canyon	Body	Base Radio																																																										
S	2008	Canyon	Body	Uplevel Radio																																																										
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2008	Canyon	Body	Theft Deterrent Module																																																										
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																	V																										
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2008	Envoy	Chassis	Electronic Brake Control Module																																																										
S	2008	Envoy	Body	Body Control Module																														V																												
S	2008	Envoy	Body	Digital Radio Receiver																																																										
S	2008	Envoy	Body	Disc Player and Video Display																																																										
S	2008	Envoy	Body	Driver Door Module																																																										
S	2008	Envoy	Body	Driver Seat Module																																																										
S	2008	Envoy	Body	Generator Battery Control Module																																																										
S	2008	Envoy	Body	HVAC Control Module Auto																																																										
S	2008	Envoy	Body	HVAC Control Module Manual																																																										
S	2008	Envoy	Body	Instrument Panel Cluster																																																										
S	2008	Envoy	Body	Lift Gate Module																																																										
S	2008	Envoy	Body	Passenger Door Module																																																										
S	2008	Envoy	Body	Passenger Presence System																																																										
S	2008	Envoy	Body	Uplevel Radio																																																										
S	2008	Envoy	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2008	Envoy	Body	Rear Seat Audio																																																									
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2008	Envoy	Body	Theft Deterrent Module																																																										
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																V																											
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																										
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
S	2009	Canyon	Chassis	Electronic Brake Control Module																																																										
S	2009	Canyon	Body	Body Control Module																														V																											
S	2009	Canyon	Body	Digital Radio Receiver																																																									
S	2009	Canyon	Body	Generator Battery Control Module																																																									
S	2009	Canyon	Body	Instrument Panel Cluster																																																									
S	2009	Canyon	Body	Passenger Presence System																																																									
S	2009	Canyon	Body	Base Radio																																																									
S	2009	Canyon	Body	Uplevel Radio																																																									
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																																									
S	2009	Canyon	Body	Theft Deterrent Module																																																									
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																									
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																									
S	2009	Envoy	Chassis	Electronic Brake Control Module																																																									
S	2009	Envoy	Body	Body Control Module																														V																											
S	2009	Envoy	Body	Digital Radio Receiver																																																									
S	2009	Envoy	Body	Disc Player and Video Display																																																									
S	2009	Envoy	Body	Driver Door Module																																																									
S	2009	Envoy	Body	Driver Seat Module																																																									
S	2009	Envoy	Body	Generator Battery Control Module																																																									
S	2009	Envoy	Body	HVAC Control Module Auto																																																									
S	2009	Envoy	Body	HVAC Control Module Manual																																																									
S	2009	Envoy	Body	Instrument Panel Cluster																																																									
S	2009	Envoy	Body	Lift Gate Module																																																									
S	2009	Envoy	Body	Passenger Door Module																																																									
S	2009	Envoy	Body	Passenger Presence System																																																									
S	2009	Envoy	Body	Uplevel Radio																																																									
S	2009	Envoy	Body	Navigation Radio																																																									
S	2009	Envoy	Body	Rear Seat Audio																																																									
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																																									
S	2009	Envoy	Body	Theft Deterrent Module																																																									
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																									
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
S	2010	ALL	Chassis	Electronic Brake Control Module																																																									
S	2010	ALL	Body	Body Control Module																														V																											
S	2010	ALL	Body	Digital Radio Receiver																																																								
S	2010	ALL	Body	Generator Battery Control Module																																																								
S	2010	ALL	Body	Instument Panel Cluster																																																								
S	2010	ALL	Body	Passenger Presence System																																																								
S	2010	ALL	Body	Personal Audio Link Module																																																								
S	2010	ALL	Body	Base Radio																																																								
S	2010	ALL	Body	Uplevel Radio																																																								
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
S	2010	ALL	Body	Theft Deterrent Module																																																								
S	2010	ALL	Body	Vehicle Comm. Interface Module																																	V		V																					
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																								
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																								
T	2004	Sonoma	Body	Body Control Module																														V																											
T	2004	Sonoma	Body	Instrument Panel Cluster																																																								
T	2004	Sonoma	Body	Base Radio																																																								
T	2004	Sonoma	Body	Uplevel Radio																																																								
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																								
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																								
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																								
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																								
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																								
T	2004	Canyon	Chassis	ABS Without Traction Control																																																								
T	2004	Canyon	Chassis	ABS With Traction Control																																																								
T	2004	Canyon	Body	Body Control Module																														V																											
T	2004	Canyon	Body	Instrument Panel Cluster																																																								
T	2004	Canyon	Body	OnStar																																	V																					
T	2004	Canyon	Body	Base Radio																																																								
T	2004	Canyon	Body	Uplevel Radio																																																								
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																																								
T	2004	Canyon	Body	Instrument Panel Cluster																																																								
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																								
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																								
T	2004	Envoy	Chassis	ABS Without Traction Control																																																								
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																								
T	2004	Envoy	Body	Amplifier (Bose)																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2004	Envoy	Body	Body Control Module																																																								
T	2004	Envoy	Body	Driver Door Module																																																								
T	2004	Envoy	Body	Driver Seat Module																																																								
T	2004	Envoy	Body	Heating and Air Conditioning Auto																																																								
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																																								
T	2004	Envoy	Body	Instrument Panel Cluster																																																								
T	2004	Envoy	Body	Lift Gate Module																																																								
T	2004	Envoy	Body	OnStar																																	V																							
T	2004	Envoy	Body	Passenger Door Module																																																								
T	2004	Envoy	Body	Uplevel Radio																																																								
T	2004	Envoy	Body	Navigation Radio																																																								
T	2004	Envoy	Body	Rear Seat Audio																																																								
T	2004	Envoy	Body	Rear Seat Entertainment																																																								
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																																								
T	2004	Envoy	Body	Vehicle Theft Deterrent																																																								
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																								
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																								
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																								
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																								
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																								
T	2004	Envoy XL	Body	Amplifier (Bose)																																																								
T	2004	Envoy XL	Body	Body Control Module																																																								
T	2004	Envoy XL	Body	Driver Door Module																																																								
T	2004	Envoy XL	Body	Driver Seat Module																																																								
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																								
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																								
T	2004	Envoy XL	Body	Instrument Panel Cluster																																																								
T	2004	Envoy XL	Body	Lift Gate Module																																																								
T	2004	Envoy XL	Body	OnStar																																	V																							
T	2004	Envoy XL	Body	Passenger Door Module																																																								
T	2004	Envoy XL	Body	Uplevel Radio																																																								
T	2004	Envoy XL	Body	Navigation Radio																																																								
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																								
T	2004	Envoy XL	Body	Rear HVAC Manual																																																								
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																								
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																								
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																								
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																								
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																								
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																								
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																								
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																								
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2004	Envoy XUV	Body	Body Control Module																																																									
T	2004	Envoy XUV	Body	Driver Door Module																																																										
T	2004	Envoy XUV	Body	Driver Seat Module																																																										
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																										
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																																										
T	2004	Envoy XUV	Body	Lift Gate Module																																																										
T	2004	Envoy XUV	Body	OnStar																																V																											
T	2004	Envoy XUV	Body	Passenger Door Module																																																										
T	2004	Envoy XUV	Body	Uplevel Radio																																																										
T	2004	Envoy XUV	Body	Navigation Radio																																																										
T	2004	Envoy XUV	Body	Rear Seat Audio																																																										
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																										
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																										
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Jimmy	Body	Body Control Module																														V																											
T	2004	Jimmy	Body	Heating and Air Conditioning																																																										
T	2004	Jimmy	Body	Instrument Panel Cluster																																																										
T	2004	Jimmy	Body	Memory Seat Module																																																										
T	2004	Jimmy	Body	Base Radio																																																										
T	2004	Jimmy	Body	Uplevel Radio																																																										
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																										
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2005	Canyon	Chassis	ABS Without Traction Control																																																										
T	2005	Canyon	Chassis	ABS With Traction Control																																																										
T	2005	Canyon	Body	Body Control Module																														V																											
T	2005	Canyon	Body	Instrument Panel Cluster																																																										
T	2005	Canyon	Body	Base Radio																																																										
T	2005	Canyon	Body	Uplevel Radio																																																										
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																V																										
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2005	Envoy	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy	Body	Body Control Module																																																										
T	2005	Envoy	Body	Disc Player and Video Display																																																										
T	2005	Envoy	Body	Driver Door Module																																																										
T	2005	Envoy	Body	Driver Seat Module																																																										
T	2005	Envoy	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																																									
T	2005	Envoy	Body	Instrument Panel Cluster																																																										
T	2005	Envoy	Body	Lift Gate Module																																																										
T	2005	Envoy	Body	Passenger Door Module																																																										
T	2005	Envoy	Body	Passenger Presence System																																																										
T	2005	Envoy	Body	Uplevel Radio																																																										
T	2005	Envoy	Body	Navigation Radio																																																										
T	2005	Envoy	Body	Rear Seat Audio																																																										
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																	V																											
T	2005	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy XL	Body	Body Control Module																																																										
T	2005	Envoy XL	Body	Disc Player and Video Display																																																										
T	2005	Envoy XL	Body	Driver Door Module																																																										
T	2005	Envoy XL	Body	Driver Seat Module																																																										
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2005	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2005	Envoy XL	Body	Lift Gate Module																																																										
T	2005	Envoy XL	Body	Passenger Door Module																																																										
T	2005	Envoy XL	Body	Passenger Presence System																																																										
T	2005	Envoy XL	Body	Uplevel Radio																																																										
T	2005	Envoy XL	Body	Navigation Radio																																																										
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2005	Envoy XL	Body	Rear HVAC Manual																																																										
T	2005	Envoy XL	Body	Rear Seat Audio																																																										
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																	V																											
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy XUV	Body	Body Control Module																																																										
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																										
T	2005	Envoy XUV	Body	Driver Door Module																																																										
T	2005	Envoy XUV	Body	Driver Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																									
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																																										
T	2005	Envoy XUV	Body	Lift Gate Module																																																										
T	2005	Envoy XUV	Body	Passenger Door Module																																																										
T	2005	Envoy XUV	Body	Passenger Presence System																																																										
T	2005	Envoy XUV	Body	Uplevel Radio																																																										
T	2005	Envoy XUV	Body	Navigation Radio																																																										
T	2005	Envoy XUV	Body	Rear Seat Audio																																																										
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																V																										
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																										
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Jimmy	Body	Body Control Module																														V																												
T	2005	Jimmy	Body	Heating and Air Conditioning																																																										
T	2005	Jimmy	Body	Instrument Panel Cluster																																																										
T	2005	Jimmy	Body	Memory Seat Module																																																										
T	2005	Jimmy	Body	Base Radio																																																										
T	2005	Jimmy	Body	Uplevel Radio																																																										
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																										
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																										
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Sonoma	Body	Body Control Module																														V																												
T	2005	Sonoma	Body	Instrument Panel Cluster																																																										
T	2005	Sonoma	Body	Base Radio																																																										
T	2005	Sonoma	Body	Uplevel Radio																																																										
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																										
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2006	Canyon	Chassis	ABS Without Traction Control																																																										
T	2006	Canyon	Chassis	ABS With Traction Control																																																										
T	2006	Canyon	Body	Body Control Module																														V																												
T	2006	Canyon	Body	Instrument Panel Cluster																																																										
T	2006	Canyon	Body	Passenger Presence System																																																										
T	2006	Canyon	Body	Base Radio																																																										
T	2006	Canyon	Body	Uplevel Radio																																																										
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																V																										
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
T	2006	Envoy	Chassis	ABS/TCS/VSES																																																								
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																								
T	2006	Envoy	Body	Body Control Module																															V																									
T	2006	Envoy	Body	Disc Player and Video Display																																																								
T	2006	Envoy	Body	Driver Door Module																																																								
T	2006	Envoy	Body	Driver Seat Module																																																								
T	2006	Envoy	Body	Heating and Air Conditioning Auto																																																								
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																																								
T	2006	Envoy	Body	Instrument Panel Cluster																																																								
T	2006	Envoy	Body	Lift Gate Module																																																								
T	2006	Envoy	Body	Passenger Door Module																																																								
T	2006	Envoy	Body	Passenger Presence System																																																								
T	2006	Envoy	Body	Uplevel Radio																																																								
T	2006	Envoy	Body	Navigation Radio																																																								
T	2006	Envoy	Body	Rear Seat Audio																																																								
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																																								
T	2006	Envoy	Body	Vehicle Theft Deterrent																																																								
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																	V																							
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																								
T	2006	Envoy XL	Body	Body Control Module																															V																									
T	2006	Envoy XL	Body	Disc Player and Video Display																																																								
T	2006	Envoy XL	Body	Driver Door Module																																																								
T	2006	Envoy XL	Body	Driver Seat Module																																																								
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																								
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																								
T	2006	Envoy XL	Body	Instrument Panel Cluster																																																								
T	2006	Envoy XL	Body	Lift Gate Module																																																								
T	2006	Envoy XL	Body	Passenger Door Module																																																								
T	2006	Envoy XL	Body	Passenger Presence System																																																								
T	2006	Envoy XL	Body	Uplevel Radio																																																								
T	2006	Envoy XL	Body	Navigation Radio																																																								
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																								
T	2006	Envoy XL	Body	Rear HVAC Manual																																																								
T	2006	Envoy XL	Body	Rear Seat Audio																																																								
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																								
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																								
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																	V																							
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																										
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																										
T	2007	Canyon	Body	Body Control Module																														V																												
T	2007	Canyon	Body	Digital Radio Receiver																																																										
T	2007	Canyon	Body	Generator Battery Control Module																																																										
T	2007	Canyon	Body	Instrument Panel Cluster																																																										
T	2007	Canyon	Body	Passenger Presence System																																																										
T	2007	Canyon	Body	Base Radio																																																										
T	2007	Canyon	Body	Uplevel Radio																																																										
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																	V																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																										
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																										
T	2007	Envoy	Chassis	Electronic Brake Control Module																																																										
T	2007	Envoy	Body	Body Control Module																														V																												
T	2007	Envoy	Body	Digital Radio Receiver																																																										
T	2007	Envoy	Body	Disc Player and Video Display																																																										
T	2007	Envoy	Body	Driver Door Module																																																										
T	2007	Envoy	Body	Driver Seat Module																																																										
T	2007	Envoy	Body	Generator Battery Control Module																																																										
T	2007	Envoy	Body	HVAC Control Module Auto																																																										
T	2007	Envoy	Body	HVAC Control Module Manual																																																										
T	2007	Envoy	Body	Instrument Panel Cluster																																																										
T	2007	Envoy	Body	Lift Gate Module																																																										
T	2007	Envoy	Body	Passenger Door Module																																																										
T	2007	Envoy	Body	Passenger Presence System																																																										
T	2007	Envoy	Body	Uplevel Radio																																																										
T	2007	Envoy	Body	Navigation Radio																																																										
T	2007	Envoy	Body	Rear Seat Audio																																																										
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2007	Envoy	Body	Theft Deterrent Module																																																										
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																	V																										
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2008	Canyon	Body	Body Control Module																															V																											
T	2008	Canyon	Body	Digital Radio Receiver																																																									
T	2008	Canyon	Body	Generator Battery Control Module																																																									
T	2008	Canyon	Body	Instrument Panel Cluster																																																									
T	2008	Canyon	Body	Passenger Presence System																																																									
T	2008	Canyon	Body	Base Radio																																																									
T	2008	Canyon	Body	Uplevel Radio																																																									
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																																									
T	2008	Canyon	Body	Theft Deterrent Module																																																									
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																	V																									
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																									
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
T	2008	Envoy	Chassis	Electronic Brake Control Module																																																									
T	2008	Envoy	Body	Body Control Module																															V																											
T	2008	Envoy	Body	Digital Radio Receiver																																																									
T	2008	Envoy	Body	Disc Player and Video Display																																																									
T	2008	Envoy	Body	Driver Door Module																																																									
T	2008	Envoy	Body	Driver Seat Module																																																									
T	2008	Envoy	Body	Generator Battery Control Module																																																									
T	2008	Envoy	Body	HVAC Control Module Auto																																																									
T	2008	Envoy	Body	HVAC Control Module Manual																																																									
T	2008	Envoy	Body	Instrument Panel Cluster																																																									
T	2008	Envoy	Body	Lift Gate Module																																																									
T	2008	Envoy	Body	Passenger Door Module																																																									
T	2008	Envoy	Body	Passenger Presence System																																																									
T	2008	Envoy	Body	Uplevel Radio																																																									
T	2008	Envoy	Body	Navigation Radio																																																									
T	2008	Envoy	Body	Rear Seat Audio																																																									
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																																									
T	2008	Envoy	Body	Theft Deterrent Module																																																									
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																	V																									
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																									
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																									
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																									
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																									
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																									
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																									
T	2009	Canyon	Chassis	Electronic Brake Control Module																																																									
T	2009	Canyon	Body	Body Control Module																															V																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2009	Canyon	Body	Digital Radio Receiver																																																									
T	2009	Canyon	Body	Generator Battery Control Module																																																										
T	2009	Canyon	Body	Instrument Panel Cluster																																																										
T	2009	Canyon	Body	Passenger Presence System																																																										
T	2009	Canyon	Body	Base Radio																																																										
T	2009	Canyon	Body	Uplevel Radio																																																										
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2009	Canyon	Body	Theft Deterrent Module																																																										
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																										
T	2009	Envoy	Body	Body Control Module																														V																												
T	2009	Envoy	Body	Digital Radio Receiver																																																										
T	2009	Envoy	Body	Disc Player and Video Display																																																										
T	2009	Envoy	Body	Driver Door Module																																																										
T	2009	Envoy	Body	Driver Seat Module																																																										
T	2009	Envoy	Body	Generator Battery Control Module																																																										
T	2009	Envoy	Body	HVAC Control Module Auto																																																										
T	2009	Envoy	Body	HVAC Control Module Manual																																																										
T	2009	Envoy	Body	Instrument Panel Cluster																																																										
T	2009	Envoy	Body	Lift Gate Module																																																										
T	2009	Envoy	Body	Passenger Door Module																																																										
T	2009	Envoy	Body	Passenger Presence System																																																										
T	2009	Envoy	Body	Uplevel Radio																																																										
T	2009	Envoy	Body	Navigation Radio																																																										
T	2009	Envoy	Body	Rear Seat Audio																																																										
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2009	Envoy	Body	Theft Deterrent Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
T	2010	ALL	Chassis	Electronic Brake Control Module																																																										
T	2010	ALL	Body	Body Control Module																														V																												
T	2010	ALL	Body	Digital Radio Receiver																																																										
T	2010	ALL	Body	Generator Battery Control Module																																																										
T	2010	ALL	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
T	2010	ALL	Body	Passenger Presence System																																																								
T	2010	ALL	Body	Personal Audio Link Module																																																								
T	2010	ALL	Body	Base Radio																																																								
T	2010	ALL	Body	Uplevel Radio																																																								
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2010	ALL	Body	Theft Deterrent Module																																																								
T	2010	ALL	Body	Vehicle Comm. Interface Module																																V		V																							
V	2007	ALL	Powertrain	Engine Control Module																																																								
V	2007	ALL	Powertrain	Rear Drive System																																																								
V	2007	ALL	Powertrain	Transmission Control Module																																																								
V	2007	ALL	Chassis	Electronic Brake Control Module																																																								
V	2007	ALL	Body	Body Control Module																																																								
V	2007	ALL	Body	Digital Radio Receiver																																																								
V	2007	ALL	Body	Driver Door Switch																																																								
V	2007	ALL	Body	Head Up Display																																																								
V	2007	ALL	Body	Heated Seat Module																																																								
V	2007	ALL	Body	HVAC Control Module Auto																																											V														
V	2007	ALL	Body	HVAC Control Module Manual																																											V														
V	2007	ALL	Body	Instrument Panel Cluster																																																								
V	2007	ALL	Body	Lift Gate Module																																																								
V	2007	ALL	Body	Park Assist Module																																																								
V	2007	ALL	Body	Passenger Door Switch																																																								
V	2007	ALL	Body	Passenger Presence System																																																								
V	2007	ALL	Body	Radio																																																								
V	2007	ALL	Body	Rear HVAC/RSA																																																								
V	2007	ALL	Body	Rollover Sensor																																																								
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2007	ALL	Body	Theft Deterrent Module																																																								
V	2008	ALL	Powertrain	Engine Control Module																																																								
V	2008	ALL	Powertrain	Rear Drive System																																																								
V	2008	ALL	Powertrain	Transmission Control Module																																																								
V	2008	ALL	Chassis	Electronic Brake Control Module																																																								
V	2008	ALL	Body	Body Control Module																																																								
V	2008	ALL	Body	Digital Radio Receiver																																																								
V	2008	ALL	Body	Driver Door Switch																																																								
V	2008	ALL	Body	Head Up Display																																																								
V	2008	ALL	Body	Heated Seat Module																																																								
V	2008	ALL	Body	HVAC Control Module Auto																																											V														
V	2008	ALL	Body	HVAC Control Module Manual																																											V														
V	2008	ALL	Body	Instrument Panel Cluster																																																								
V	2008	ALL	Body	Lift Gate Module																																																								
V	2008	ALL	Body	Park Assist Module																																																								
V	2008	ALL	Body	Passenger Door Switch																																																								
V	2008	ALL	Body	Passenger Presence System																																																								
V	2008	ALL	Body	Radio																																																								
V	2008	ALL	Body	Rear HVAC/RSA																																																								
V	2008	ALL	Body	Rollover Sensor																																																								
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2008	ALL	Body	Theft Deterrent Module																																																								
V	2009	ALL	Powertrain	Engine Control Module																																																								
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
V	2009	ALL	Powertrain	Rear Drive System																																																											
V	2009	ALL	Powertrain	Transmission Control Module																																																												
V	2009	ALL	Chassis	Electronic Brake Control Module																																																												
V	2009	ALL	Body	Body Control Module																																																											
V	2009	ALL	Body	Digital Radio Receiver																																																											
V	2009	ALL	Body	Driver Door Switch																																																											
V	2009	ALL	Body	Head Up Display																																																											
V	2009	ALL	Body	Heated Seat Module																																																											
V	2009	ALL	Body	HVAC Control Module Auto																																												V															
V	2009	ALL	Body	HVAC Control Module Manual																																												V															
V	2009	ALL	Body	Instrument Panel Cluster																																																											
V	2009	ALL	Body	Lift Gate Module																																																											
V	2009	ALL	Body	Park Assist Module																																																											
V	2009	ALL	Body	Passenger Door Switch																																																											
V	2009	ALL	Body	Passenger Presence System																																																											
V	2009	ALL	Body	Radio																																																											
V	2009	ALL	Body	Rear HVAC/RSA																																																											
V	2009	ALL	Body	Rollover Sensor																																																											
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2009	ALL	Body	Theft Deterrent Module																																																											
V	2010	ALL	Powertrain	Engine Control Module																																																											
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2010	ALL	Powertrain	Rear Drive System																																																											
V	2010	ALL	Powertrain	Transmission Control Module																																																											
V	2010	ALL	Chassis	Electronic Brake Control Module																																																											
V	2010	ALL	Body	Body Control Module																																																											
V	2010	ALL	Body	Digital Radio Receiver																																																											
V	2010	ALL	Body	Driver Door Switch																																																											
V	2010	ALL	Body	Head Up Display																																																											
V	2010	ALL	Body	Heated Seat Module																																																											
V	2010	ALL	Body	HVAC Control Module Auto																																												V															
V	2010	ALL	Body	HVAC Control Module Manual																																												V															
V	2010	ALL	Body	Instrument Panel Cluster																																																											
V	2010	ALL	Body	Lift Gate Module																																																											
V	2010	ALL	Body	Park Assist Module																																																											
V	2010	ALL	Body	Passenger Door Switch																																																											
V	2010	ALL	Body	Passenger Presence System																																																											
V	2010	ALL	Body	Radio																																																											
V	2010	ALL	Body	Rear HVAC/RSA																																																											
V	2010	ALL	Body	Supplemental Inflatable Restraint																									V	V																																	
V	2010	ALL	Body	Theft Deterrent Module																																																											
V	2011	ALL	Powertrain	Engine Control Module																																																											
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2011	ALL	Powertrain	Rear Drive System																																																											
V	2011	ALL	Powertrain	Transmission Control Module																																																											
V	2011	ALL	Chassis	Electronic Brake Control Module																																																											
V	2011	ALL	Body	Body Control Module																																																											
V	2011	ALL	Body	Digital Radio Receiver																																																											
V	2011	ALL	Body	Driver Door Switch																																																											
V	2011	ALL	Body	Head Up Display																																																											
V	2011	ALL	Body	Heated Seat Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
V	2011	ALL	Body	HVAC Control Module Auto																																												V											
V	2011	ALL	Body	HVAC Control Module Manual																																												V											
V	2011	ALL	Body	Instrument Panel Cluster																																																							
V	2011	ALL	Body	Lift Gate Module																																																							
V	2011	ALL	Body	Park Assist Module																																																							
V	2011	ALL	Body	Passenger Door Switch																																																							
V	2011	ALL	Body	Passenger Presence System																																																							
V	2011	ALL	Body	Radio																																																							
V	2011	ALL	Body	Rear HVAC/RSA																																																							
V	2011	ALL	Body	Supplemental Inflatable Restraint																									V	V																														
V	2011	ALL	Body	Theft Deterrent Module																																																							
V	2012	ALL	Powertrain	Engine Control Module																				V																																				
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																							
V	2012	ALL	Powertrain	Rear Drive System																																																							
V	2012	ALL	Powertrain	Transmission Control Module																																																							
V	2012	ALL	Chassis	Electronic Brake Control Module																																																							
V	2012	ALL	Body	Body Control Module																																																							
V	2012	ALL	Body	Digital Radio Receiver																																																							
V	2012	ALL	Body	Driver Door Switch																																																							
V	2012	ALL	Body	Head Up Display																																																							
V	2012	ALL	Body	Heated Seat Module																																																							
V	2012	ALL	Body	HVAC Control Module Auto																																												V											
V	2012	ALL	Body	HVAC Control Module Manual																																												V											
V	2012	ALL	Body	Instrument Panel Cluster																																																							
V	2012	ALL	Body	Lift Gate Module																																																							
V	2012	ALL	Body	Park Assist Module																																																							
V	2012	ALL	Body	Passenger Door Switch																																																							
V	2012	ALL	Body	Passenger Presence System																																																							
V	2012	ALL	Body	Radio																																																							
V	2012	ALL	Body	Rear HVAC/RSA																																																							
V	2012	ALL	Body	Supplemental Inflatable Restraint																									V	V																														
V	2012	ALL	Body	Theft Deterrent Module																																																							
V	2013	ALL	Powertrain	Engine Control Module																				V																																				
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																							
V	2013	ALL	Powertrain	Rear Drive System																																																							
V	2013	ALL	Powertrain	Transmission Control Module																																																							
V	2013	ALL	Chassis	Electronic Brake Control Module																																																							
V	2013	ALL	Body	Body Control Module																																																							
V	2013	ALL	Body	Digital Radio Receiver																																																							
V	2013	ALL	Body	Driver Door Switch																																																							
V	2013	ALL	Body	Head Up Display																																																							
V	2013	ALL	Body	Heated Seat Module																																																							
V	2013	ALL	Body	HVAC Control Module Auto																																												V											
V	2013	ALL	Body	HVAC Control Module Manual																																												V											
V	2013	ALL	Body	Instrument Panel Cluster																																																							
V	2013	ALL	Body	Left Side Object Detection Module																																																							
V	2013	ALL	Body	Lift Gate Module																																																							
V	2013	ALL	Body	Park Assist Module																																																							
V	2013	ALL	Body	Passenger Door Switch																																																							
V	2013	ALL	Body	Passenger Presence System																																																							
V	2013	ALL	Body	Radio																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
V	2013	ALL	Body	Rear HVAC/RSA																																																								
V	2013	ALL	Body	Right Side Object Detection Module																																																								
V	2013	ALL	Body	Supplemental Inflatable Restraint																									V	V																														
V	2013	ALL	Body	Theft Deterrent Module																																																							
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																				
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
V	2014	Acadia	Powertrain	Chassis Control Module																																																								
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																								
V	2014	Acadia	Chassis	Electronic Brake Control Module					V																																																			
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate						V	V	V						V				V	V	V																																				
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)						V	V	V						V				V	V	V																																				
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
V	2014	Acadia	Body	Passenger Presence Module																										V						V																								
V	2014	Acadia	Body	Instrument Cluster																																																								
V	2014	Acadia	Body	Head-Up Display Module																																																								
V	2014	Acadia	Body	Radio																																																								
V	2014	Acadia	Body	Rear Audio Control Module																																																								
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																								
V	2014	Acadia	Body	Personal Audio Link Control Module																																																								
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																				
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																				
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																									V	V		V	V									
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																									V	V		V	V									
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																	V																																						
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																								
V	2014	Acadia	Body	Liftgate Control Module																																																								
V	2014	Acadia	Body	Seat Memory Control Module																																						V	V																	
V	2014	Acadia	Body	Front Seat Heating Control Module																																						V	V																	
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																								
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																								
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																								
V	2014	Acadia	Body	Parking Assist Control Module																															V																								
V	2014	Acadia	Body	Frontview Camera Module																																																								
V	2014	Acadia	Body	Theft Deterrent Module										V																																														
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																				
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																								
V	2015	Acadia	Chassis	Electronic Brake Control Module					V																																																			
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate						V	V	V						V				V	V	V																																				
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)						V	V	V						V				V	V	V																																				
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
V	2015	Acadia	Body	Passenger Presence Module																										V						V																								
V	2015	Acadia	Body	Instrument Cluster																																																								
V	2015	Acadia	Body	Head-Up Display Module																																																								
V	2015	Acadia	Body	Radio																																																								
V	2015	Acadia	Body	Rear Audio Control Module																																																								
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																								
V	2015	Acadia	Body	Personal Audio Link Control Module																																																								
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																				
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																				
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																									V	V		V	V									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																											V	V		V	V								
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																	V																																						
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																							
V	2015	Acadia	Body	Liftgate Control Module																																																						
V	2015	Acadia	Body	Seat Memory Control Module																																					V	V																	
V	2015	Acadia	Body	Front Seat Heating Control Module																																					V	V																	
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																						
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																						
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																						
V	2015	Acadia	Body	Parking Assist Control Module																																V																							
V	2015	Acadia	Body	Frontview Camera Module																																																						
V	2015	Acadia	Body	Theft Deterrent Module										V																																												
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																				V																																			
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																						
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																						
V	2016	Acadia	Chassis	Electronic Brake Control Module					V																																																	
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate						V	V	V						V				V	V	V																																		
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)						V	V	V						V				V	V	V																																		
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																							
V	2016	Acadia	Body	Passenger Presence Module																										V						V																						
V	2016	Acadia	Body	Instrument Cluster																																																					
V	2016	Acadia	Body	Head-Up Display Module																																																					
V	2016	Acadia	Body	Radio																																																					
V	2016	Acadia	Body	Rear Audio Control Module																																																					
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																					
V	2016	Acadia	Body	Personal Audio Link Control Module																																																					
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																	V	V	V																			
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																										V	V		V	V								
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																										V	V		V	V								
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																	V																																						
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																						
V	2016	Acadia	Body	Liftgate Control Module																																																						
V	2016	Acadia	Body	Seat Memory Control Module																																					V	V																	
V	2016	Acadia	Body	Front Seat Heating Control Module																																					V	V																	
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																						
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																						
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																						
V	2016	Acadia	Body	Parking Assist Control Module																																V																						
V	2016	Acadia	Body	Frontview Camera Module																																																						
V	2016	Acadia	Body	Theft Deterrent Module										V																																												
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																						
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																						
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																						
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																						
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																						
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																						
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																						
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																						
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
1	2011	Sierra	Chassis	Electronic Suspension Control																																																												
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																												
1	2011	Sierra	Body	Amplifier (Bose)																																																												
1	2011	Sierra	Body	Body Control Module																																																												
1	2011	Sierra	Body	Body Control Module (aux.)																																																												
1	2011	Sierra	Body	Digital Radio Receiver																																																												
1	2011	Sierra	Body	Driver Door Switch																																																												
1	2011	Sierra	Body	HVAC Control Module Auto																																												V																
1	2011	Sierra	Body	HVAC Control Module Manual																																												V																
1	2011	Sierra	Body	Instrument Panel Cluster																																																												
1	2011	Sierra	Body	Memory Seat Module																																																												
1	2011	Sierra	Body	Park Assist Module																																																												
1	2011	Sierra	Body	Passenger Door Switch																																																												
1	2011	Sierra	Body	Passenger Presence System																																																												
1	2011	Sierra	Body	Radio																																																											
1	2011	Sierra	Body	Rear Heated Seat Module																																																											
1	2011	Sierra	Body	Rear HVAC/RSA																																																											
1	2011	Sierra	Body	Supplemental Inflatable Restraint																									V	V																																
1	2011	Sierra	Body	Theft Deterrent Module																																																											
1	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																											
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																											
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																											
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																											
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																											
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																											
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																											
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																											
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																											
1	2011	Sierra Hybrid	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																									
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																									
1	2011	Sierra Hybrid	Body	Driver Door Switch																																																									
1	2011	Sierra Hybrid	Body	Heated Seat Module																																																									
1	2011	Sierra Hybrid	Body	HVAC Control Module																																												V													
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																									
1	2011	Sierra Hybrid	Body	Park Assist Module																																																									
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																																									
1	2011	Sierra Hybrid	Body	Passenger Presence System																																																									
1	2011	Sierra Hybrid	Body	Radio																																																									
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																									
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																									
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																									
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																									V	V																															
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																									
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2011	Yukon	Chassis	Electronic Brake Control Module																																																									
1	2011	Yukon	Chassis	Electronic Suspension Control																																																									
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																									
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																									
1	2011	Yukon	Body	Amplifier (Bose)																																																									
1	2011	Yukon	Body	Assist Step Controller																																																									
1	2011	Yukon	Body	Body Control Module																																																									
1	2011	Yukon	Body	Body Control Module (aux.)																																																									
1	2011	Yukon	Body	Digital Radio Receiver																																																									
1	2011	Yukon	Body	Driver Door Switch																																																									
1	2011	Yukon	Body	HVAC Control Module Auto																																												V													
1	2011	Yukon	Body	HVAC Control Module Manual																																												V													
1	2011	Yukon	Body	Instrument Panel Cluster																																																									
1	2011	Yukon	Body	Left Side Object Detection Module																																																									
1	2011	Yukon	Body	Lift Gate Module																																																									
1	2011	Yukon	Body	Memory Seat Module																																																									
1	2011	Yukon	Body	Park Assist Module																																																									
1	2011	Yukon	Body	Passenger Door Switch																																																									
1	2011	Yukon	Body	Passenger Presence System																																																									
1	2011	Yukon	Body	Radio																																																									
1	2011	Yukon	Body	Rear Heated Seat Module																																																									
1	2011	Yukon	Body	Rear HVAC/RSA																																																									
1	2011	Yukon	Body	Right Side Object Detection Module																																																									
1	2011	Yukon	Body	Supplemental Inflatable Restraint																									V	V																															
1	2011	Yukon	Body	Theft Deterrent Module																																																									
1	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																									
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																									
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																									
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																									
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																									
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																									
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																									
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																									
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																									
1	2011	Yukon Hybrid	Body	Body Control Module																																																									
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																									
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																									
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																									
1	2011	Yukon Hybrid	Body	HVAC Control Module																																												V														
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																									
1	2011	Yukon Hybrid	Body	Lift Gate Module																																																									
1	2011	Yukon Hybrid	Body	Park Assist Module																																																									
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																									
1	2011	Yukon Hybrid	Body	Passenger Presence System																																																									
1	2011	Yukon Hybrid	Body	Radio																																																									
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																									V	V																															
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																									
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																									
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																									
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																									
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
1	2011	Yukon XL	Body	Amplifier (Bose)																																																									
1	2011	Yukon XL	Body	Assist Step Controller																																																									
1	2011	Yukon XL	Body	Body Control Module																																																									
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																									
1	2011	Yukon XL	Body	Digital Radio Receiver																																																									
1	2011	Yukon XL	Body	Driver Door Switch																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2011	Yukon XL	Body	HVAC Control Module Auto																																												V											
1	2011	Yukon XL	Body	HVAC Control Module Manual																																												V											
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																							
1	2011	Yukon XL	Body	Left Side Object Detection Module																																																							
1	2011	Yukon XL	Body	Lift Gate Module																																																							
1	2011	Yukon XL	Body	Memory Seat Module																																																							
1	2011	Yukon XL	Body	Park Assist Module																																																							
1	2011	Yukon XL	Body	Passenger Door Switch																																																							
1	2011	Yukon XL	Body	Passenger Presence System																																																							
1	2011	Yukon XL	Body	Radio																																																							
1	2011	Yukon XL	Body	Rear Heated Seat Module																																																							
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																							
1	2011	Yukon XL	Body	Right Side Object Detection Module																																																							
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																									V	V																													
1	2011	Yukon XL	Body	Theft Deterrent Module																																																							
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																							
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																							
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																							
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																							
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																							
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																							
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																							
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																							
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																							
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																							
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																							
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																							
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																							
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																							
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																							
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																							
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																							
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																							
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																							
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																							
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																							
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																							
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																							
1	2012	Sierra	Chassis	Electronic Suspension Control																																																							
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																							
1	2012	Sierra	Body	Amplifier (Bose)																																																							
1	2012	Sierra	Body	Body Control Module																																																							
1	2012	Sierra	Body	Body Control Module (aux.)																																																							
1	2012	Sierra	Body	Digital Radio Receiver																																																							
1	2012	Sierra	Body	Driver Door Switch																																																							
1	2012	Sierra	Body	HVAC Control Module Auto																																												V											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2012	Sierra	Body	HVAC Control Module Manual																																												V											
1	2012	Sierra	Body	Instrument Panel Cluster																																																						
1	2012	Sierra	Body	Memory Seat Module																																																						
1	2012	Sierra	Body	Park Assist Module																																																					
1	2012	Sierra	Body	Passenger Door Switch																																																					
1	2012	Sierra	Body	Passenger Presence System																																																					
1	2012	Sierra	Body	Radio																																																					
1	2012	Sierra	Body	Navigation Radio																																																					
1	2012	Sierra	Body	Rear Heated Seat Module																																																					
1	2012	Sierra	Body	Rear HVAC/RSA																																																					
1	2012	Sierra	Body	Supplemental Inflatable Restraint																									V	V																												
1	2012	Sierra	Body	Theft Deterrent Module																																																					
1	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																					
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																					
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																					
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																					
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																					
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																					
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																					
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																					
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																					
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																					
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																					
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																					
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																					
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																					
1	2012	Sierra Hybrid	Body	Body Control Module																																																					
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																					
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																					
1	2012	Sierra Hybrid	Body	Driver Door Switch																																																					
1	2012	Sierra Hybrid	Body	Heated Seat Module																																																					
1	2012	Sierra Hybrid	Body	HVAC Control Module																																												V											
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																					
1	2012	Sierra Hybrid	Body	Park Assist Module																																																					
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																																					
1	2012	Sierra Hybrid	Body	Passenger Presence System																																																					
1	2012	Sierra Hybrid	Body	Radio																																																					
1	2012	Sierra Hybrid	Body	Navigation Radio																																																					
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																					
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																					
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																					
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																									V	V																												
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																					
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																					
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																					
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																					
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																					
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																					
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																					
1	2012	Yukon	Chassis	Electronic Brake Control Module																																																					
1	2012	Yukon	Chassis	Electronic Suspension Control																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																												
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
1	2012	Yukon	Body	Amplifier (Bose)																																																												
1	2012	Yukon	Body	Assist Step Controller																																																												
1	2012	Yukon	Body	Body Control Module																																																												
1	2012	Yukon	Body	Body Control Module (aux.)																																																												
1	2012	Yukon	Body	Digital Radio Receiver																																																												
1	2012	Yukon	Body	Driver Door Switch																																																												
1	2012	Yukon	Body	HVAC Control Module Auto																																												V																
1	2012	Yukon	Body	HVAC Control Module Manual																																												V																
1	2012	Yukon	Body	Instrument Panel Cluster																																																												
1	2012	Yukon	Body	Left Side Object Detection Module																																																												
1	2012	Yukon	Body	Lift Gate Module																																																												
1	2012	Yukon	Body	Memory Seat Module																																																												
1	2012	Yukon	Body	Park Assist Module																																																												
1	2012	Yukon	Body	Passenger Door Switch																																																												
1	2012	Yukon	Body	Passenger Presence System																																																												
1	2012	Yukon	Body	Radio																																																												
1	2012	Yukon	Body	Navigation Radio																																																												
1	2012	Yukon	Body	Rear Heated Seat Module																																																												
1	2012	Yukon	Body	Rear HVAC/RSA																																																												
1	2012	Yukon	Body	Right Side Object Detection Module																																																												
1	2012	Yukon	Body	Supplemental Inflatable Restraint																									V	V																																		
1	2012	Yukon	Body	Theft Deterrent Module																																																												
1	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																												
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																												
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																												
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																												
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																												
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																												
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																												
1	2012	Yukon Hybrid	Body	Body Control Module																																																												
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																												
1	2012	Yukon Hybrid	Body	Driver Door Switch																																																												
1	2012	Yukon Hybrid	Body	Heated Seat Module																																																												
1	2012	Yukon Hybrid	Body	HVAC Control Module																																												V																
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
1	2012	Yukon Hybrid	Body	Lift Gate Module																																																												
1	2012	Yukon Hybrid	Body	Park Assist Module																																																												
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																																												
1	2012	Yukon Hybrid	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2012	Yukon Hybrid	Body	Radio																																																								
1	2012	Yukon Hybrid	Body	Navigation Radio																																																								
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																									V	V																														
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																								
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																								
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																								
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																								
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																								
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																								
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																								
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
1	2012	Yukon XL	Body	Amplifier (Bose)																																																								
1	2012	Yukon XL	Body	Assist Step Controller																																																								
1	2012	Yukon XL	Body	Body Control Module																																																								
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																								
1	2012	Yukon XL	Body	Digital Radio Receiver																																																								
1	2012	Yukon XL	Body	Driver Door Switch																																																								
1	2012	Yukon XL	Body	HVAC Control Module Auto																																																								
1	2012	Yukon XL	Body	HVAC Control Module Manual																																																								
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																								
1	2012	Yukon XL	Body	Left Side Object Detection Module																																																								
1	2012	Yukon XL	Body	Lift Gate Module																																																								
1	2012	Yukon XL	Body	Memory Seat Module																																																								
1	2012	Yukon XL	Body	Park Assist Module																																																								
1	2012	Yukon XL	Body	Passenger Door Switch																																																								
1	2012	Yukon XL	Body	Passenger Presence System																																																								
1	2012	Yukon XL	Body	Radio																																																								
1	2012	Yukon XL	Body	Navigation Radio																																																								
1	2012	Yukon XL	Body	Rear Heated Seat Module																																																								
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																								
1	2012	Yukon XL	Body	Right Side Object Detection Module																																																								
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																									V	V																														
1	2012	Yukon XL	Body	Theft Deterrent Module																																																								
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																										
1	2013	Sierra	Chassis	Electronic Suspension Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Body	Amplifier (Bose)																																																										
1	2013	Sierra	Body	Body Control Module																																																										
1	2013	Sierra	Body	Body Control Module (aux.)																																																										
1	2013	Sierra	Body	Digital Radio Receiver																																																										
1	2013	Sierra	Body	Driver Door Switch																																																										
1	2013	Sierra	Body	HVAC Control Module Auto																																												V														
1	2013	Sierra	Body	HVAC Control Module Manual																																												V														
1	2013	Sierra	Body	Instrument Panel Cluster																																																										
1	2013	Sierra	Body	Memory Seat Module																																																										
1	2013	Sierra	Body	Park Assist Module																																																										
1	2013	Sierra	Body	Passenger Door Switch																																																										
1	2013	Sierra	Body	Passenger Presence System																																																										
1	2013	Sierra	Body	Radio																																																										
1	2013	Sierra	Body	Navigation Radio																																																										
1	2013	Sierra	Body	Rear Heated Seat Module																																																										
1	2013	Sierra	Body	Rear HVAC/RSA																																																										
1	2013	Sierra	Body	Supplemental Inflatable Restraint																									V	V																																
1	2013	Sierra	Body	Theft Deterrent Module																																																										
1	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																									
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																									
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																									
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																									
1	2013	Sierra Hybrid	Body	Body Control Module																																																									
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																									
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																									
1	2013	Sierra Hybrid	Body	Driver Door Switch																																																									
1	2013	Sierra Hybrid	Body	Heated Seat Module																																																									
1	2013	Sierra Hybrid	Body	HVAC Control Module																																												V														
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																									
1	2013	Sierra Hybrid	Body	Park Assist Module																																																									
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																																									
1	2013	Sierra Hybrid	Body	Passenger Presence System																																																									
1	2013	Sierra Hybrid	Body	Radio																																																									
1	2013	Sierra Hybrid	Body	Navigation Radio																																																									
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																									
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																									
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																									
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																									V	V																															
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																									
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2013	Yukon	Chassis	Electronic Brake Control Module																																																									
1	2013	Yukon	Chassis	Electronic Suspension Control																																																									
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Yukon	Body	Amplifier (Bose)																																																									
1	2013	Yukon	Body	Assist Step Controller																																																									
1	2013	Yukon	Body	Body Control Module																																																									
1	2013	Yukon	Body	Body Control Module (aux.)																																																									
1	2013	Yukon	Body	Digital Radio Receiver																																																									
1	2013	Yukon	Body	Driver Door Switch																																																									
1	2013	Yukon	Body	HVAC Control Module Auto																																												V														
1	2013	Yukon	Body	HVAC Control Module Manual																																												V														
1	2013	Yukon	Body	Instrument Panel Cluster																																																									
1	2013	Yukon	Body	Left Side Object Detection Module																																																									
1	2013	Yukon	Body	Lift Gate Module																																																									
1	2013	Yukon	Body	Memory Seat Module																																																									
1	2013	Yukon	Body	Park Assist Module																																																									
1	2013	Yukon	Body	Passenger Door Switch																																																									
1	2013	Yukon	Body	Passenger Presence System																																																									
1	2013	Yukon	Body	Radio																																																									
1	2013	Yukon	Body	Navigation Radio																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2013	Yukon	Body	Rear Heated Seat Module																																																										
1	2013	Yukon	Body	Rear HVAC/RSA																																																										
1	2013	Yukon	Body	Right Side Object Detection Module																																																										
1	2013	Yukon	Body	Supplemental Inflatable Restraint																									V	V																																
1	2013	Yukon	Body	Theft Deterrent Module																																																										
1	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																										
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2013	Yukon Hybrid	Body	Body Control Module																																																										
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2013	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2013	Yukon Hybrid	Body	Heated Seat Module																																																										
1	2013	Yukon Hybrid	Body	HVAC Control Module																																												V														
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
1	2013	Yukon Hybrid	Body	Lift Gate Module																																																										
1	2013	Yukon Hybrid	Body	Park Assist Module																																																										
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2013	Yukon Hybrid	Body	Passenger Presence System																																																										
1	2013	Yukon Hybrid	Body	Radio																																																										
1	2013	Yukon Hybrid	Body	Navigation Radio																																																										
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																										
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon XL	Body	Amplifier (Bose)																																																										
1	2013	Yukon XL	Body	Assist Step Controller																																																										
1	2013	Yukon XL	Body	Body Control Module																																																										
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2013	Yukon XL	Body	Digital Radio Receiver																																																										
1	2013	Yukon XL	Body	Driver Door Switch																																																										
1	2013	Yukon XL	Body	HVAC Control Module Auto																																																										
1	2013	Yukon XL	Body	HVAC Control Module Manual																																																										
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																										
1	2013	Yukon XL	Body	Left Side Object Detection Module																																																										
1	2013	Yukon XL	Body	Lift Gate Module																																																										
1	2013	Yukon XL	Body	Memory Seat Module																																																										
1	2013	Yukon XL	Body	Park Assist Module																																																										
1	2013	Yukon XL	Body	Passenger Door Switch																																																										
1	2013	Yukon XL	Body	Passenger Presence System																																																										
1	2013	Yukon XL	Body	Radio																																																										
1	2013	Yukon XL	Body	Navigation Radio																																																										
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																										
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																										
1	2013	Yukon XL	Body	Right Side Object Detection Module																																																										
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																									V	V																																
1	2013	Yukon XL	Body	Theft Deterrent Module																																																										
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																						
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																						
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																						
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																						
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																				
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control						V																																																				
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2014	Sierra	Chassis	Electronic Brake Control Module					V																																																					
1	2014	Sierra	Chassis	Parking Brake Control Module																																																										
1	2014	Sierra	Chassis	Power Steering Control Module																																																										
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
1	2014	Sierra	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V	V		V	V																								V										
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																											
1	2014	Sierra	Body	Passenger Presence Module																															V																											
1	2014	Sierra	Body	Instrument Cluster																																V																										
1	2014	Sierra	Body	Radio Control																																																										
1	2014	Sierra	Body	HVAC Control																																																										
1	2014	Sierra	Body	Radio																																																										
1	2014	Sierra	Body	Amplifier																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2014	Sierra	Body	Media Disc Player																																																								
1	2014	Sierra	Body	Human Machine Interface Control Module																																																								
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																															V												V	V	V		V									
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																															V												V	V	V		V									
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																															V												V	V	V		V									
1	2014	Sierra	Body	Parking Assist Control Module																																	V																							
1	2014	Sierra	Body	Frontview Camera Module																																																								
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																								
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																								
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																								
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																								
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																								
1	2014	Sierra HD	Chassis	Suspension Control Module																																																								
1	2014	Sierra HD	Body	Body Control Module						V	V	V						V				V	V	V																																				
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
1	2014	Sierra HD	Body	Instrument Cluster																																																								
1	2014	Sierra HD	Body	Base Radio																																																								
1	2014	Sierra HD	Body	Navigation Radio																																																								
1	2014	Sierra HD	Body	Uplevel Radio																																																								
1	2014	Sierra HD	Body	Amplifier																																																								
1	2014	Sierra HD	Body	Rear Audio Control Module																																																								
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																								
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																								
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																		V	V	V	V																			
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																		V	V	V																				
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																											V	V			V									
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																											V	V			V									
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																											V	V			V									
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																											V	V			V									
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																	V																																							
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																								
1	2014	Sierra HD	Body	Seat Memory Control Module																																					V	V																		
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																								
1	2014	Sierra HD	Body	Parking Assist Control Module																																																								
1	2014	Sierra HD	Body	Theft Deterrent Module										V																																														
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																								
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																								
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump						V																																																		
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
1	2014	Yukon	Chassis	Electronic Brake Control Module																																																									
1	2014	Yukon	Chassis	Parking Brake Control Module																																																								
1	2014	Yukon	Chassis	Suspension Control Module																																																								
1	2014	Yukon	Body	Body Control Module						V	V	V						V				V	V	V																																				
1	2014	Yukon	Body	Auxiliary Body Control Module																																																								
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
1	2014	Yukon	Body	Passenger Presence Module																										V																														
1	2014	Yukon	Body	Instrument Cluster																																																								
1	2014	Yukon	Body	Base Radio																																																								
1	2014	Yukon	Body	Navigation Radio																																																								
1	2014	Yukon	Body	Uplevel Radio																																																								
1	2014	Yukon	Body	Amplifier																																																								
1	2014	Yukon	Body	Rear Audio Control Module																																																								
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																																								
1	2014	Yukon	Body	Personal Audio Link Control Module																																																								
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																				
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																				
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																										V	V			V								
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																										V	V			V								
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																	V																																							
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																								
1	2014	Yukon	Body	Liftgate Control Module																																																								
1	2014	Yukon	Body	Seat Memory Control Module																																				V	V																			
1	2014	Yukon	Body	Rear Seat Heating Control Module																																						V	V																
1	2014	Yukon	Body	Assist Step Control Module																																																								
1	2014	Yukon	Body	Right Side Object Detection Control Module																																								V	V														
1	2014	Yukon	Body	Left Side Object Detection Control Module																																								V	V														
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																																								
1	2014	Yukon	Body	Parking Assist Control Module																																																								
1	2014	Yukon	Body	Theft Deterrent Module										V																																														
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																								
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																								
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																								
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																								
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump						V																																																		
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																								
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																																								
1	2014	Yukon XL	Chassis	Suspension Control Module																																																								
1	2014	Yukon XL	Body	Body Control Module						V	V	V						V				V	V	V																																				
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																																								
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
1	2014	Yukon XL	Body	Passenger Presence Module																										V																														
1	2014	Yukon XL	Body	Instrument Cluster																																																								
1	2014	Yukon XL	Body	Base Radio																																																								
1	2014	Yukon XL	Body	Navigation Radio																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2014	Yukon XL	Body	Uplevel Radio																																																										
1	2014	Yukon XL	Body	Amplifier																																																										
1	2014	Yukon XL	Body	Rear Audio Control Module																																																										
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																										
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																																										
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																						
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																							
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																										V	V			V												
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																										V	V			V												
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																	V																																									
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Yukon XL	Body	Liftgate Control Module																																																										
1	2014	Yukon XL	Body	Seat Memory Control Module																																					V	V																				
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																							V	V																		
1	2014	Yukon XL	Body	Assist Step Control Module																																																										
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																									V	V																
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																									V	V																
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																										
1	2014	Yukon XL	Body	Parking Assist Control Module																																																										
1	2014	Yukon XL	Body	Theft Deterrent Module										V																																																
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																						
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																						
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																						
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																						
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																						
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																						
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																					
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control						V																																																				
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Sierra	Chassis	Electronic Brake Control Module					V																																																					
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Sierra	Chassis	Power Steering Control Module																																																										
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module				V	V																																																					
1	2015	Sierra	Chassis	Suspension Control Module																																																										
1	2015	Sierra	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																									V									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
1	2015	Sierra	Body	Passenger Presence Module																																V																							
1	2015	Sierra	Body	Instrument Cluster																																	V																						
1	2015	Sierra	Body	Radio Controls																																																						
1	2015	Sierra	Body	HVAC Controls																																																						
1	2015	Sierra	Body	Radio																																																						
1	2015	Sierra	Body	Amplifier																																																						
1	2015	Sierra	Body	Media Disc Player																																																						
1	2015	Sierra	Body	Human Machine Interface Control Module																																																						
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																	V	V	V	V																			
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																			
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V	V		V								
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																														V												V	V	V		V								
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																														V												V	V	V		V								
1	2015	Sierra	Body	Parking Assist Control Module																																V																							
1	2015	Sierra	Body	Frontview Camera Module																																																						
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																			
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																						
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																			
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																						
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																						
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																															
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control						V																																															
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																						
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																						
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																						
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																						
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																						
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																						
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																						
1	2015	Yukon	Chassis	Electronic Brake Control Module					V																																																	
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																						
1	2015	Yukon	Chassis	Parking Brake Control Module																																																						
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																						
1	2015	Yukon	Chassis	Power Steering Control Module																																																						
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
1	2015	Yukon	Chassis	Suspension Control Module																																																						
1	2015	Yukon	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																							V							
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
1	2015	Yukon	Body	Passenger Presence Module																																V																							
1	2015	Yukon	Body	Instrument Cluster																																	V																						
1	2015	Yukon	Body	Radio Controls																																																					
1	2015	Yukon	Body	HVAC Controls																																																					
1	2015	Yukon	Body	Radio																																																					
1	2015	Yukon	Body	Amplifier																																																					
1	2015	Yukon	Body	Media Disc Player																																																					
1	2015	Yukon	Body	Human Machine Interface Control Module																																																					
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																	V	V	V	V																			
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																			
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2015	Yukon	Body	HVAC Control Module																															V												V	V	V		V								
1	2015	Yukon	Body	Liftgate Control Module																																																							
1	2015	Yukon	Body	Keyless Entry Control Module																																																							
1	2015	Yukon	Body	Assist Step Control Module																																																						
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																						
1	2015	Yukon	Body	Parking Assist Control Module																																V																							
1	2015	Yukon	Body	Frontview Camera Module																																																						
1	2015	Yukon	Body	Steering Column Lock Control Module																																																						
1	2015	Yukon	Body	Battery Energy Control Module																																																						
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																			
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																						
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																			
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																						
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																						
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control						V																																																
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																						
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																						
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																						
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																						
1	2015	Yukon XL	Chassis	Electronic Brake Control Module					V																																																	
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																						
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																						
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																						
1	2015	Yukon XL	Chassis	Power Steering Control Module																																																						
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module				V	V																																																	
1	2015	Yukon XL	Chassis	Suspension Control Module																																																						
1	2015	Yukon XL	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																							V							
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																							
1	2015	Yukon XL	Body	Passenger Presence Module																																V																							
1	2015	Yukon XL	Body	Instrument Cluster																																	V																					
1	2015	Yukon XL	Body	Radio Controls																																																					
1	2015	Yukon XL	Body	HVAC Controls																																																					
1	2015	Yukon XL	Body	Radio																																																					
1	2015	Yukon XL	Body	Amplifier																																																					
1	2015	Yukon XL	Body	Media Disc Player																																																					
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																					
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																	V	V	V	V																		
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																			
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
1	2015	Yukon XL	Body	HVAC Control Module																															V												V	V	V		V								
1	2015	Yukon XL	Body	Liftgate Control Module																																																						
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																						
1	2015	Yukon XL	Body	Assist Step Control Module																																																						
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																						
1	2015	Yukon XL	Body	Parking Assist Control Module																																V																							
1	2015	Yukon XL	Body	Frontview Camera Module																																																						
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																						
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																			
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																			
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																								
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																								
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																				V																																				
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																								
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																						V	V
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																							
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																								
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																								
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																								
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
1	2016	Sierra	Chassis	Electronic Brake Control Module					V																																																			
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																								
1	2016	Sierra	Chassis	Parking Brake Control Module																																																								
1	2016	Sierra	Chassis	Power Steering Control Module																																																				V				
1	2016	Sierra	Chassis	Power Steering Control Module																																																								
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
1	2016	Sierra	Chassis	Suspension Control Module																																																								
1	2016	Sierra	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																								V						
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
1	2016	Sierra	Body	Passenger Presence Module																																V																								
1	2016	Sierra	Body	Instrument Cluster																																	V																						
1	2016	Sierra	Body	Radio Controls																																																							
1	2016	Sierra	Body	HVAC Controls																																																							
1	2016	Sierra	Body	Radio (IO3)																																																							
1	2016	Sierra	Body	Radio (IOB)																																																							
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																							
1	2016	Sierra	Body	Amplifier																																																							
1	2016	Sierra	Body	Media Disc Player																																																							
1	2016	Sierra	Body	Human Machine Interface Control Module																																																							
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V	V		V									
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																														V												V	V	V		V									
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																														V												V	V	V		V									
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																							
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																							
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																							
1	2016	Sierra	Body	Parking Assist Control Module																																	V																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2016	Sierra	Body	Frontview Camera Module																																																								
1	2016	Sierra	Body	Frontview Camera Module																																																								
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																							
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																							
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																							
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																							
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																							
1	2016	Yukon	Chassis	Electronic Brake Control Module					V																																																			
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																							
1	2016	Yukon	Chassis	Parking Brake Control Module																																																							
1	2016	Yukon	Chassis	Power Steering Control Module																																																							
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
1	2016	Yukon	Chassis	Suspension Control Module																																																							
1	2016	Yukon	Body	Body Control Module																																																							
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V	V																										
1	2016	Yukon	Body	Passenger Presence Module																															V																									
1	2016	Yukon	Body	Instrument Cluster																																V																							
1	2016	Yukon	Body	Radio Controls																																																						
1	2016	Yukon	Body	HVAC Controls																																																						
1	2016	Yukon	Body	Radio																																																						
1	2016	Yukon	Body	Amplifier																																																						
1	2016	Yukon	Body	Media Disc Player																																																						
1	2016	Yukon	Body	Human Machine Interface Control Module																																																						
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																	V	V	V																				
1	2016	Yukon	Body	HVAC Control Module																														V													V	V	V		V								
1	2016	Yukon	Body	Liftgate Control Module																																																						
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																						
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																						
1	2016	Yukon	Body	Keyless Entry Control Module																																																						
1	2016	Yukon	Body	Assist Step Control Module																																																						
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																						
1	2016	Yukon	Body	Parking Assist Control Module																																V																							
1	2016	Yukon	Body	Frontview Camera Module																																																						
1	2016	Yukon	Body	Steering Column Lock Control Module																																																						
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																							
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																							
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																							
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																							
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																							
1	2016	Yukon XL	Chassis	Electronic Brake Control Module					V																																																		
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																							
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																							
1	2016	Yukon XL	Chassis	Power Steering Control Module																																																							
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
1	2016	Yukon XL	Chassis	Suspension Control Module																																																							
1	2016	Yukon XL	Body	Body Control Module																																																							
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																								V	V	V	V	V	V	V																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
1	2016	Yukon XL	Body	Passenger Presence Module																																V																								
1	2016	Yukon XL	Body	Instrument Cluster																																	V																							
1	2016	Yukon XL	Body	Radio Controls																																																								
1	2016	Yukon XL	Body	HVAC Controls																																																								
1	2016	Yukon XL	Body	Radio																																																								
1	2016	Yukon XL	Body	Amplifier																																																								
1	2016	Yukon XL	Body	Media Disc Player																																																								
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																								
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																	V	V	V																				
1	2016	Yukon XL	Body	HVAC Control Module																														V												V	V	V		V									
1	2016	Yukon XL	Body	Liftgate Control Module																																																								
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																								
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																								
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																								
1	2016	Yukon XL	Body	Assist Step Control Module																																																								
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																								
1	2016	Yukon XL	Body	Parking Assist Control Module																																	V																							
1	2016	Yukon XL	Body	Frontview Camera Module																																																								
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																								
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																								
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																								
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
2	2011	Sierra	Chassis	Electronic Suspension Control																																																								
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																								
2	2011	Sierra	Body	Amplifier (Bose)																																																								
2	2011	Sierra	Body	Body Control Module																																																								
2	2011	Sierra	Body	Body Control Module (aux.)																																																								
2	2011	Sierra	Body	Digital Radio Receiver																																																								
2	2011	Sierra	Body	Driver Door Switch																																																								
2	2011	Sierra	Body	HVAC Control Module Auto																																												V													
2	2011	Sierra	Body	HVAC Control Module Manual																																												V													
2	2011	Sierra	Body	Instrument Panel Cluster																																																								
2	2011	Sierra	Body	Memory Seat Module																																																								
2	2011	Sierra	Body	Park Assist Module																																																								
2	2011	Sierra	Body	Passenger Door Switch																																																								
2	2011	Sierra	Body	Passenger Presence System																																																								
2	2011	Sierra	Body	Radio																																																								
2	2011	Sierra	Body	Rear Heated Seat Module																																																								
2	2011	Sierra	Body	Rear HVAC/RSA																																																								
2	2011	Sierra	Body	Supplemental Inflatable Restraint																									V	V																														
2	2011	Sierra	Body	Theft Deterrent Module																																																								
2	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																								
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																								
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																								
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																								
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																								
2	2011	Sierra Hybrid	Body	Body Control Module																																																								
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																								
2	2011	Sierra Hybrid	Body	Driver Door Switch																																																								
2	2011	Sierra Hybrid	Body	Heated Seat Module																																																								
2	2011	Sierra Hybrid	Body	HVAC Control Module																																												V													
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
2	2011	Sierra Hybrid	Body	Park Assist Module																																																								
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																																								
2	2011	Sierra Hybrid	Body	Passenger Presence System																																																								
2	2011	Sierra Hybrid	Body	Radio																																																								
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																											
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																	
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																											
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																											
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																											
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
2	2011	Yukon	Chassis	Electronic Brake Control Module																																																											
2	2011	Yukon	Chassis	Electronic Suspension Control																																																											
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																											
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
2	2011	Yukon	Body	Amplifier (Bose)																																																											
2	2011	Yukon	Body	Assist Step Controller																																																											
2	2011	Yukon	Body	Body Control Module																																																											
2	2011	Yukon	Body	Body Control Module (aux.)																																																											
2	2011	Yukon	Body	Digital Radio Receiver																																																											
2	2011	Yukon	Body	Driver Door Switch																																																											
2	2011	Yukon	Body	HVAC Control Module Auto																																												V															
2	2011	Yukon	Body	HVAC Control Module Manual																																												V															
2	2011	Yukon	Body	Instrument Panel Cluster																																																											
2	2011	Yukon	Body	Left Side Object Detection Module																																																											
2	2011	Yukon	Body	Lift Gate Module																																																											
2	2011	Yukon	Body	Memory Seat Module																																																											
2	2011	Yukon	Body	Park Assist Module																																																											
2	2011	Yukon	Body	Passenger Door Switch																																																											
2	2011	Yukon	Body	Passenger Presence System																																																											
2	2011	Yukon	Body	Radio																																																										
2	2011	Yukon	Body	Rear Heated Seat Module																																																											
2	2011	Yukon	Body	Rear HVAC/RSA																																																											
2	2011	Yukon	Body	Right Side Object Detection Module																																																											
2	2011	Yukon	Body	Supplemental Inflatable Restraint																									V	V																																	
2	2011	Yukon	Body	Theft Deterrent Module																																																											
2	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																											
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																											
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																									
2	2011	Yukon Hybrid	Body	Body Control Module																																																										
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2011	Yukon Hybrid	Body	Driver Door Switch																																																										
2	2011	Yukon Hybrid	Body	Heated Seat Module																																																										
2	2011	Yukon Hybrid	Body	HVAC Control Module																																													V													
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
2	2011	Yukon Hybrid	Body	Lift Gate Module																																																										
2	2011	Yukon Hybrid	Body	Park Assist Module																																																										
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																																										
2	2011	Yukon Hybrid	Body	Passenger Presence System																																																										
2	2011	Yukon Hybrid	Body	Radio																																																										
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																										
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon XL	Body	Amplifier (Bose)																																																										
2	2011	Yukon XL	Body	Assist Step Controller																																																										
2	2011	Yukon XL	Body	Body Control Module																																																										
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																										
2	2011	Yukon XL	Body	Digital Radio Receiver																																																										
2	2011	Yukon XL	Body	Driver Door Switch																																																										
2	2011	Yukon XL	Body	HVAC Control Module Auto																																													V													
2	2011	Yukon XL	Body	HVAC Control Module Manual																																													V													
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																										
2	2011	Yukon XL	Body	Left Side Object Detection Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2011	Yukon XL	Body	Lift Gate Module																																																											
2	2011	Yukon XL	Body	Memory Seat Module																																																												
2	2011	Yukon XL	Body	Park Assist Module																																																												
2	2011	Yukon XL	Body	Passenger Door Switch																																																												
2	2011	Yukon XL	Body	Passenger Presence System																																																												
2	2011	Yukon XL	Body	Radio																																																												
2	2011	Yukon XL	Body	Rear Heated Seat Module																																																												
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																												
2	2011	Yukon XL	Body	Right Side Object Detection Module																																																												
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																									V	V																																		
2	2011	Yukon XL	Body	Theft Deterrent Module																																																												
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
2	2012	Sierra	Chassis	Electronic Suspension Control																																																												
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																												
2	2012	Sierra	Body	Amplifier (Bose)																																																												
2	2012	Sierra	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2012	Sierra	Body	Body Control Module (aux.)																																																												
2	2012	Sierra	Body	Digital Radio Receiver																																																												
2	2012	Sierra	Body	Driver Door Switch																																																												
2	2012	Sierra	Body	HVAC Control Module Auto																																												V															
2	2012	Sierra	Body	HVAC Control Module Manual																																												V															
2	2012	Sierra	Body	Instrument Panel Cluster																																																											
2	2012	Sierra	Body	Memory Seat Module																																																												
2	2012	Sierra	Body	Park Assist Module																																																												
2	2012	Sierra	Body	Passenger Door Switch																																																												
2	2012	Sierra	Body	Passenger Presence System																																																												
2	2012	Sierra	Body	Radio																																																											
2	2012	Sierra	Body	Navigation Radio																																																											
2	2012	Sierra	Body	Rear Heated Seat Module																																																												
2	2012	Sierra	Body	Rear HVAC/RSA																																																												
2	2012	Sierra	Body	Supplemental Inflatable Restraint																									V	V																																		
2	2012	Sierra	Body	Theft Deterrent Module																																																												
2	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																												
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																												
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																												
2	2012	Sierra Hybrid	Body	Body Control Module																																																												
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																												
2	2012	Sierra Hybrid	Body	Driver Door Switch																																																												
2	2012	Sierra Hybrid	Body	Heated Seat Module																																																												
2	2012	Sierra Hybrid	Body	HVAC Control Module																																												V															
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
2	2012	Sierra Hybrid	Body	Park Assist Module																																																												
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																																												
2	2012	Sierra Hybrid	Body	Passenger Presence System																																																												
2	2012	Sierra Hybrid	Body	Radio																																																												
2	2012	Sierra Hybrid	Body	Navigation Radio																																																												
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																									V	V																																		
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																												
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
2	2012	Yukon	Chassis	Electronic Brake Control Module																																																											
2	2012	Yukon	Chassis	Electronic Suspension Control																																																											
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																											
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
2	2012	Yukon	Body	Amplifier (Bose)																																																											
2	2012	Yukon	Body	Assist Step Controller																																																											
2	2012	Yukon	Body	Body Control Module																																																											
2	2012	Yukon	Body	Body Control Module (aux.)																																																											
2	2012	Yukon	Body	Digital Radio Receiver																																																											
2	2012	Yukon	Body	Driver Door Switch																																																											
2	2012	Yukon	Body	HVAC Control Module Auto																																												V															
2	2012	Yukon	Body	HVAC Control Module Manual																																												V															
2	2012	Yukon	Body	Instrument Panel Cluster																																																											
2	2012	Yukon	Body	Left Side Object Detection Module																																																											
2	2012	Yukon	Body	Lift Gate Module																																																											
2	2012	Yukon	Body	Memory Seat Module																																																											
2	2012	Yukon	Body	Park Assist Module																																																											
2	2012	Yukon	Body	Passenger Door Switch																																																											
2	2012	Yukon	Body	Passenger Presence System																																																											
2	2012	Yukon	Body	Radio																																																											
2	2012	Yukon	Body	Navigation Radio																																																											
2	2012	Yukon	Body	Rear Heated Seat Module																																																											
2	2012	Yukon	Body	Rear HVAC/RSA																																																											
2	2012	Yukon	Body	Right Side Object Detection Module																																																											
2	2012	Yukon	Body	Supplemental Inflatable Restraint																									V	V																																
2	2012	Yukon	Body	Theft Deterrent Module																																																											
2	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																											
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																											
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																											
2	2012	Yukon Hybrid	Body	Body Control Module																																																											
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																											
2	2012	Yukon Hybrid	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2012	Yukon Hybrid	Body	Heated Seat Module																																																									
2	2012	Yukon Hybrid	Body	HVAC Control Module																																													V												
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																									
2	2012	Yukon Hybrid	Body	Lift Gate Module																																																									
2	2012	Yukon Hybrid	Body	Park Assist Module																																																									
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																																									
2	2012	Yukon Hybrid	Body	Passenger Presence System																																																									
2	2012	Yukon Hybrid	Body	Radio																																																									
2	2012	Yukon Hybrid	Body	Navigation Radio																																																									
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																									V	V																															
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																									
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																									
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																									
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																									
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																									
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																									
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																									
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																									
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																									
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
2	2012	Yukon XL	Body	Amplifier (Bose)																																																									
2	2012	Yukon XL	Body	Assist Step Controller																																																									
2	2012	Yukon XL	Body	Body Control Module																																																									
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																									
2	2012	Yukon XL	Body	Digital Radio Receiver																																																									
2	2012	Yukon XL	Body	Driver Door Switch																																																									
2	2012	Yukon XL	Body	HVAC Control Module Auto																																													V												
2	2012	Yukon XL	Body	HVAC Control Module Manual																																													V												
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																									
2	2012	Yukon XL	Body	Left Side Object Detection Module																																																									
2	2012	Yukon XL	Body	Lift Gate Module																																																									
2	2012	Yukon XL	Body	Memory Seat Module																																																									
2	2012	Yukon XL	Body	Park Assist Module																																																									
2	2012	Yukon XL	Body	Passenger Door Switch																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2012	Yukon XL	Body	Passenger Presence System																																																								
2	2012	Yukon XL	Body	Radio																																																								
2	2012	Yukon XL	Body	Navigation Radio																																																								
2	2012	Yukon XL	Body	Rear Heated Seat Module																																																								
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																								
2	2012	Yukon XL	Body	Right Side Object Detection Module																																																								
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																									V	V																														
2	2012	Yukon XL	Body	Theft Deterrent Module																																																								
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																								
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																								
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																								
2	2013	Sierra	Chassis	Electronic Suspension Control																																																								
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra	Body	Amplifier (Bose)																																																								
2	2013	Sierra	Body	Body Control Module																																																								
2	2013	Sierra	Body	Body Control Module (aux.)																																																								
2	2013	Sierra	Body	Digital Radio Receiver																																																								
2	2013	Sierra	Body	Driver Door Switch																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2013	Sierra	Body	HVAC Control Module Auto																																												V											
2	2013	Sierra	Body	HVAC Control Module Manual																																												V											
2	2013	Sierra	Body	Instrument Panel Cluster																																																							
2	2013	Sierra	Body	Memory Seat Module																																																							
2	2013	Sierra	Body	Park Assist Module																																																							
2	2013	Sierra	Body	Passenger Door Switch																																																							
2	2013	Sierra	Body	Passenger Presence System																																																							
2	2013	Sierra	Body	Radio																																																							
2	2013	Sierra	Body	Navigation Radio																																																							
2	2013	Sierra	Body	Rear Heated Seat Module																																																							
2	2013	Sierra	Body	Rear HVAC/RSA																																																							
2	2013	Sierra	Body	Supplemental Inflatable Restraint																									V	V																														
2	2013	Sierra	Body	Theft Deterrent Module																																																							
2	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																							
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																							
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																						
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																						
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																						
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																						
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																						
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																						
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																						
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																						
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																						
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																						
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																						
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																						
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																						
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																						
2	2013	Sierra Hybrid	Body	Body Control Module																																																						
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																						
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																						
2	2013	Sierra Hybrid	Body	Driver Door Switch																																																						
2	2013	Sierra Hybrid	Body	Heated Seat Module																																																						
2	2013	Sierra Hybrid	Body	HVAC Control Module																																												V											
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																						
2	2013	Sierra Hybrid	Body	Park Assist Module																																																						
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																																						
2	2013	Sierra Hybrid	Body	Passenger Presence System																																																						
2	2013	Sierra Hybrid	Body	Radio																																																						
2	2013	Sierra Hybrid	Body	Navigation Radio																																																						
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																						
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																						
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																						
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																									V	V																													
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																						
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																						
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																						
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																						
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2013	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Body	Amplifier (Bose)																																																										
2	2013	Yukon	Body	Assist Step Controller																																																										
2	2013	Yukon	Body	Body Control Module																																																										
2	2013	Yukon	Body	Body Control Module (aux.)																																																										
2	2013	Yukon	Body	Digital Radio Receiver																																																										
2	2013	Yukon	Body	Driver Door Switch																																																										
2	2013	Yukon	Body	HVAC Control Module Auto																																												V														
2	2013	Yukon	Body	HVAC Control Module Manual																																												V														
2	2013	Yukon	Body	Instrument Panel Cluster																																																										
2	2013	Yukon	Body	Left Side Object Detection Module																																																										
2	2013	Yukon	Body	Lift Gate Module																																																										
2	2013	Yukon	Body	Memory Seat Module																																																										
2	2013	Yukon	Body	Park Assist Module																																																										
2	2013	Yukon	Body	Passenger Door Switch																																																										
2	2013	Yukon	Body	Passenger Presence System																																																										
2	2013	Yukon	Body	Radio																																																										
2	2013	Yukon	Body	Navigation Radio																																																										
2	2013	Yukon	Body	Rear Heated Seat Module																																																										
2	2013	Yukon	Body	Rear HVAC/RSA																																																										
2	2013	Yukon	Body	Right Side Object Detection Module																																																										
2	2013	Yukon	Body	Supplemental Inflatable Restraint																									V	V																																
2	2013	Yukon	Body	Theft Deterrent Module																																																										
2	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2013	Yukon Hybrid	Body	Body Control Module																																																										
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Yukon Hybrid	Body	Driver Door Switch																																																										
2	2013	Yukon Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2013	Yukon Hybrid	Body	HVAC Control Module																																												V											
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																						
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																						
2	2013	Yukon Hybrid	Body	Lift Gate Module																																																						
2	2013	Yukon Hybrid	Body	Park Assist Module																																																						
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																																						
2	2013	Yukon Hybrid	Body	Passenger Presence System																																																						
2	2013	Yukon Hybrid	Body	Radio																																																						
2	2013	Yukon Hybrid	Body	Navigation Radio																																																						
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																						
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																						
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																						
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																						
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																									V	V																												
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																						
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																						
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																						
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																						
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																						
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																						
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																						
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																						
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																						
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																						
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																						
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																						
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																						
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																						
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																						
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																						
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																						
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																						
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																						
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																						
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																						
2	2013	Yukon XL	Body	Amplifier (Bose)																																																						
2	2013	Yukon XL	Body	Assist Step Controller																																																						
2	2013	Yukon XL	Body	Body Control Module																																																						
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																						
2	2013	Yukon XL	Body	Digital Radio Receiver																																																						
2	2013	Yukon XL	Body	Driver Door Switch																																																						
2	2013	Yukon XL	Body	HVAC Control Module Auto																																												V											
2	2013	Yukon XL	Body	HVAC Control Module Manual																																												V											
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																						
2	2013	Yukon XL	Body	Left Side Object Detection Module																																																						
2	2013	Yukon XL	Body	Lift Gate Module																																																						
2	2013	Yukon XL	Body	Memory Seat Module																																																						
2	2013	Yukon XL	Body	Park Assist Module																																																						
2	2013	Yukon XL	Body	Passenger Door Switch																																																						
2	2013	Yukon XL	Body	Passenger Presence System																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2013	Yukon XL	Body	Radio																																																								
2	2013	Yukon XL	Body	Navigation Radio																																																								
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																								
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																								
2	2013	Yukon XL	Body	Right Side Object Detection Module																																																								
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																									V	V																														
2	2013	Yukon XL	Body	Theft Deterrent Module																																																								
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																				
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																				
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																		
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control						V																																																		
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2014	Sierra	Chassis	Electronic Brake Control Module					V																																																			
2	2014	Sierra	Chassis	Parking Brake Control Module																																																								
2	2014	Sierra	Chassis	Power Steering Control Module																																																								
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
2	2014	Sierra	Body	Body Control Module						V	V	V		V	V	V		V	V		V	V	V	V	V		V	V																												V				
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
2	2014	Sierra	Body	Passenger Presence Module																															V																									
2	2014	Sierra	Body	Instrument Cluster																																V																								
2	2014	Sierra	Body	Radio Control																																																								
2	2014	Sierra	Body	HVAC Control																																																								
2	2014	Sierra	Body	Radio																																																								
2	2014	Sierra	Body	Amplifier																																																								
2	2014	Sierra	Body	Media Disc Player																																																								
2	2014	Sierra	Body	Human Machine Interface Control Module																																																								
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V	V		V										
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																														V												V	V	V		V										
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																														V												V	V	V		V									
2	2014	Sierra	Body	Parking Assist Control Module																															V																									
2	2014	Sierra	Body	Frontview Camera Module																																																								
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																								
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																								
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																								
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2014	Sierra HD	Chassis	Suspension Control Module																																																								
2	2014	Sierra HD	Body	Body Control Module						V	V	V						V				V	V	V																																				
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
2	2014	Sierra HD	Body	Instrument Cluster																																																								
2	2014	Sierra HD	Body	Base Radio																																																								
2	2014	Sierra HD	Body	Navigation Radio																																																								
2	2014	Sierra HD	Body	Uplevel Radio																																																								
2	2014	Sierra HD	Body	Amplifier																																																								
2	2014	Sierra HD	Body	Rear Audio Control Module																																																								
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																								
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																								
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																					
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																										V	V			V								
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																										V	V			V								
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																										V	V			V								
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																										V	V			V								
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																	V																																						
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																							
2	2014	Sierra HD	Body	Seat Memory Control Module																																					V	V																		
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																							
2	2014	Sierra HD	Body	Parking Assist Control Module																																																							
2	2014	Sierra HD	Body	Theft Deterrent Module										V																																													
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																							
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																							
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																							
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																							
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump						V																																																	
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																							
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																							
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																							
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																							
2	2014	Yukon	Chassis	Parking Brake Control Module																																																							
2	2014	Yukon	Chassis	Suspension Control Module																																																							
2	2014	Yukon	Body	Body Control Module						V	V	V						V				V	V	V																																				
2	2014	Yukon	Body	Auxiliary Body Control Module																																																							
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																										
2	2014	Yukon	Body	Passenger Presence Module																										V																													
2	2014	Yukon	Body	Instrument Cluster																																																						
2	2014	Yukon	Body	Base Radio																																																						
2	2014	Yukon	Body	Navigation Radio																																																						
2	2014	Yukon	Body	Uplevel Radio																																																						
2	2014	Yukon	Body	Amplifier																																																						
2	2014	Yukon	Body	Rear Audio Control Module																																																						
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																						
2	2014	Yukon	Body	Personal Audio Link Control Module																																																						
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																				
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																				
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																										V	V			V								
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																										V	V			V								
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																	V																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																									
2	2014	Yukon	Body	Liftgate Control Module																																																										
2	2014	Yukon	Body	Seat Memory Control Module																																					V	V																			
2	2014	Yukon	Body	Rear Seat Heating Control Module																																							V	V																	
2	2014	Yukon	Body	Assist Step Control Module																																																									
2	2014	Yukon	Body	Right Side Object Detection Control Module																																									V	V															
2	2014	Yukon	Body	Left Side Object Detection Control Module																																									V	V															
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																									
2	2014	Yukon	Body	Parking Assist Control Module																																																									
2	2014	Yukon	Body	Theft Deterrent Module										V																																															
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump						V																																																			
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																										
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																										
2	2014	Yukon XL	Chassis	Suspension Control Module																																																										
2	2014	Yukon XL	Body	Body Control Module						V	V	V						V				V	V	V																																						
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																										
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																												
2	2014	Yukon XL	Body	Passenger Presence Module																										V																																
2	2014	Yukon XL	Body	Instrument Cluster																																																										
2	2014	Yukon XL	Body	Base Radio																																																										
2	2014	Yukon XL	Body	Navigation Radio																																																										
2	2014	Yukon XL	Body	Uplevel Radio																																																										
2	2014	Yukon XL	Body	Amplifier																																																										
2	2014	Yukon XL	Body	Rear Audio Control Module																																																										
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																										
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																										
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																						
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																										V	V			V										
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																										V	V			V										
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																	V																																								
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Yukon XL	Body	Liftgate Control Module																																																										
2	2014	Yukon XL	Body	Seat Memory Control Module																																					V	V																			
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																							V	V																	
2	2014	Yukon XL	Body	Assist Step Control Module																																																										
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																									V	V															
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																									V	V															
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																										
2	2014	Yukon XL	Body	Parking Assist Control Module																																																										
2	2014	Yukon XL	Body	Theft Deterrent Module										V																																															
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																						
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																						
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																						
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																						
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																						
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																				
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control						V																																																				
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Sierra	Chassis	Electronic Brake Control Module					V																																																					
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Sierra	Chassis	Power Steering Control Module																																																										
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
2	2015	Sierra	Chassis	Suspension Control Module																																																										
2	2015	Sierra	Body	Body Control Module						V	V	V	V	V	V	V		V	V		V	V	V	V	V		V	V																								V								
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
2	2015	Sierra	Body	Passenger Presence Module																																V																										
2	2015	Sierra	Body	Instrument Cluster																																	V																								
2	2015	Sierra	Body	Radio Controls																																																									
2	2015	Sierra	Body	HVAC Controls																																																									
2	2015	Sierra	Body	Radio																																																									
2	2015	Sierra	Body	Amplifier																																																									
2	2015	Sierra	Body	Media Disc Player																																																									
2	2015	Sierra	Body	Human Machine Interface Control Module																																																									
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																	V	V	V	V																				
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V	V		V									
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																														V												V	V	V		V									
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																														V												V	V	V		V									
2	2015	Sierra	Body	Parking Assist Control Module																																	V																								
2	2015	Sierra	Body	Frontview Camera Module																																																									
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																						
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																						
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																		
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control						V																																																		
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																								
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																								
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																								
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																								
2	2015	Yukon	Chassis	Electronic Brake Control Module					V																																																			
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																								
2	2015	Yukon	Chassis	Parking Brake Control Module																																																								
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																								
2	2015	Yukon	Chassis	Power Steering Control Module																																																								
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
2	2015	Yukon	Chassis	Suspension Control Module																																																								
2	2015	Yukon	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																												V				
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																										V	V	V	V	V	V	V																								
2	2015	Yukon	Body	Passenger Presence Module																																V																								
2	2015	Yukon	Body	Instrument Cluster																																	V																							
2	2015	Yukon	Body	Radio Controls																																																								
2	2015	Yukon	Body	HVAC Controls																																																								
2	2015	Yukon	Body	Radio																																																								
2	2015	Yukon	Body	Amplifier																																																								
2	2015	Yukon	Body	Media Disc Player																																																								
2	2015	Yukon	Body	Human Machine Interface Control Module																																																								
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																	V	V	V	V																				
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																					
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																					
2	2015	Yukon	Body	HVAC Control Module																															V													V	V	V		V								
2	2015	Yukon	Body	Liftgate Control Module																																																								
2	2015	Yukon	Body	Keyless Entry Control Module																																																								
2	2015	Yukon	Body	Assist Step Control Module																																																								
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																								
2	2015	Yukon	Body	Parking Assist Control Module																																V																								
2	2015	Yukon	Body	Frontview Camera Module																																																								
2	2015	Yukon	Body	Steering Column Lock Control Module																																																								
2	2015	Yukon	Body	Battery Energy Control Module																																																								
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																								
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter						V																																																		
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control						V																																																		
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																								
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2015	Yukon XL	Chassis	Electronic Brake Control Module					V																																																			

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																								
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																									
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																									
2	2015	Yukon XL	Chassis	Power Steering Control Module																																																									
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module				V	V																																																				
2	2015	Yukon XL	Chassis	Suspension Control Module																																																									
2	2015	Yukon XL	Body	Body Control Module						V	V	V		V	V	V	V	V	V		V	V	V	V	V	V	V	V																							V								
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
2	2015	Yukon XL	Body	Passenger Presence Module																																V																									
2	2015	Yukon XL	Body	Instrument Cluster																																	V																							
2	2015	Yukon XL	Body	Radio Controls																																																								
2	2015	Yukon XL	Body	HVAC Controls																																																								
2	2015	Yukon XL	Body	Radio																																																								
2	2015	Yukon XL	Body	Amplifier																																																								
2	2015	Yukon XL	Body	Media Disc Player																																																								
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																								
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																	V	V	V	V																				
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																				
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
2	2015	Yukon XL	Body	HVAC Control Module																														V												V	V	V		V									
2	2015	Yukon XL	Body	Liftgate Control Module																																																								
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																								
2	2015	Yukon XL	Body	Assist Step Control Module																																																								
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																								
2	2015	Yukon XL	Body	Parking Assist Control Module																																V																									
2	2015	Yukon XL	Body	Frontview Camera Module																																																								
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																								
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																				V																																				
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																				V																																				
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																								
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																								
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																				V																																				
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																								
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																						V	V
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																								
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																								
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																								
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2016	Sierra	Chassis	Electronic Brake Control Module					V																																																			
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																								
2	2016	Sierra	Chassis	Parking Brake Control Module																																																								
2	2016	Sierra	Chassis	Power Steering Control Module																																																			V					
2	2016	Sierra	Chassis	Power Steering Control Module																																																								
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
2	2016	Sierra	Chassis	Suspension Control Module																																																								
2	2016	Sierra	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																								V					
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
2	2016	Sierra	Body	Passenger Presence Module																																V																							
2	2016	Sierra	Body	Instrument Cluster																																	V																						
2	2016	Sierra	Body	Radio Controls																																																							
2	2016	Sierra	Body	HVAC Controls																																																							
2	2016	Sierra	Body	Radio (IO3)																																																							
2	2016	Sierra	Body	Radio (IOB)																																																							
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																							
2	2016	Sierra	Body	Amplifier																																																						
2	2016	Sierra	Body	Media Disc Player																																																						
2	2016	Sierra	Body	Human Machine Interface Control Module																																																						
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																	V	V	V																			
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																			
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																														V												V	V	V		V							
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																														V												V	V	V		V							
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																														V												V	V	V		V							
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																						
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																						
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																						
2	2016	Sierra	Body	Parking Assist Control Module																																	V																					
2	2016	Sierra	Body	Frontview Camera Module																																																						
2	2016	Sierra	Body	Frontview Camera Module																																																						
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																		
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																						
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																		
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																						
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																						
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																						
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																						
2	2016	Yukon	Chassis	Electronic Brake Control Module					V																																																		
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																							
2	2016	Yukon	Chassis	Parking Brake Control Module																																																							
2	2016	Yukon	Chassis	Power Steering Control Module																																																							
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module				V	V																																																		
2	2016	Yukon	Chassis	Suspension Control Module																																																							
2	2016	Yukon	Body	Body Control Module																																																						
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																								
2	2016	Yukon	Body	Passenger Presence Module																																V																						
2	2016	Yukon	Body	Instrument Cluster																																	V																					
2	2016	Yukon	Body	Radio Controls																																																						
2	2016	Yukon	Body	HVAC Controls																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
2	2016	Yukon	Body	Radio																																																								
2	2016	Yukon	Body	Amplifier																																																								
2	2016	Yukon	Body	Media Disc Player																																																								
2	2016	Yukon	Body	Human Machine Interface Control Module																																																								
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																	V	V	V																					
2	2016	Yukon	Body	HVAC Control Module																														V												V	V	V		V										
2	2016	Yukon	Body	Liftgate Control Module																																																								
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																								
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																								
2	2016	Yukon	Body	Keyless Entry Control Module																																																								
2	2016	Yukon	Body	Assist Step Control Module																																																								
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																								
2	2016	Yukon	Body	Parking Assist Control Module																																V																								
2	2016	Yukon	Body	Frontview Camera Module																																																								
2	2016	Yukon	Body	Steering Column Lock Control Module																																																								
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																				V																																				
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																				V																																				
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2016	Yukon XL	Chassis	Electronic Brake Control Module					V																																																			
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																								
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																								
2	2016	Yukon XL	Chassis	Power Steering Control Module																																																								
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module				V	V																																																			
2	2016	Yukon XL	Chassis	Suspension Control Module																																																								
2	2016	Yukon XL	Body	Body Control Module																																																								
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
2	2016	Yukon XL	Body	Passenger Presence Module																															V																									
2	2016	Yukon XL	Body	Instrument Cluster																																V																								
2	2016	Yukon XL	Body	Radio Controls																																																								
2	2016	Yukon XL	Body	HVAC Controls																																																								
2	2016	Yukon XL	Body	Radio																																																								
2	2016	Yukon XL	Body	Amplifier																																																								
2	2016	Yukon XL	Body	Media Disc Player																																																								
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																								
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																V	V	V																						
2	2016	Yukon XL	Body	HVAC Control Module																														V												V	V	V		V										
2	2016	Yukon XL	Body	Liftgate Control Module																																																								
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																								
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																								
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																								
2	2016	Yukon XL	Body	Assist Step Control Module																																																								
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																								
2	2016	Yukon XL	Body	Parking Assist Control Module																																V																								
2	2016	Yukon XL	Body	Frontview Camera Module																																																								
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																								
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																									
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
5	2011	ALL	Chassis	Electronic Brake Control Module																																																									
5	2011	ALL	Body	Body Control Module																														V																											
5	2011	ALL	Body	Digital Radio Receiver																																																									
5	2011	ALL	Body	Generator Battery Control Module																																																									
5	2011	ALL	Body	Instrument Panel Cluster																																																									
5	2011	ALL	Body	Passenger Presence System																																																									
5	2011	ALL	Body	Personal Audio Link Module																																																									
5	2011	ALL	Body	Base Radio																																																									
5	2011	ALL	Body	Uplevel Radio																																																									
5	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
5	2011	ALL	Body	Theft Deterrent Module																																																									
5	2011	ALL	Body	Vehicle Comm. Interface Module																																V		V																						
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																									
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
5	2012	ALL	Chassis	Electronic Brake Control Module																																																									
5	2012	ALL	Body	Body Control Module																														V																											
5	2012	ALL	Body	Digital Radio Receiver																																																									
5	2012	ALL	Body	Generator Battery Control Module																																																									
5	2012	ALL	Body	Instrument Panel Cluster																																																									
5	2012	ALL	Body	Passenger Presence System																																																									
5	2012	ALL	Body	Personal Audio Link Module																																																									
5	2012	ALL	Body	Base Radio																																																									
5	2012	ALL	Body	Uplevel Radio																																																									
5	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
5	2012	ALL	Body	Theft Deterrent Module																																																									
5	2012	ALL	Body	Vehicle Comm. Interface Module																																V		V																						
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																				
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																				
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
5	2015	Canyon	Powertrain	Chassis Control Module																																																									
5	2015	Canyon	Powertrain	Transfer Case Control Module																																																									
5	2015	Canyon	Chassis	Electronic Brake Control Module					V																																																			
5	2015	Canyon	Chassis	Power Steering Control Module				V	V																																																			
5	2015	Canyon	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																								V						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
5	2015	Canyon	Body	Passenger Presence Module																																V																								
5	2015	Canyon	Body	Radio																																																							
5	2015	Canyon	Body	Amplifier																																																							
5	2015	Canyon	Body	Human Machine Interface Control Module																																																							
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																	V	V	V																					
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V									
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V									
5	2015	Canyon	Body	Parking Assist Control Module																																V																							
5	2015	Canyon	Body	Frontview Camera Module																																																							
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																			
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																							
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																							
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																							
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																							
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																			
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																							
5	2016	Canyon	Powertrain	Transfer Case Control Module																																																							
5	2016	Canyon	Chassis	Electronic Brake Control Module					V																																																		
5	2016	Canyon	Chassis	Power Steering Control Module				V	V																																																		
5	2016	Canyon	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V						
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																									
5	2016	Canyon	Body	Passenger Presence Module																																V																								
5	2016	Canyon	Body	Trailer Interface Control Module																																	V																							
5	2016	Canyon	Body	Radio																																																							
5	2016	Canyon	Body	Amplifier																																																							
5	2016	Canyon	Body	Human Machine Interface Control Module																																																							
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																	V	V	V																					
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																														V												V	V	V	V									
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																														V												V	V	V	V									
5	2016	Canyon	Body	Frontview Camera Module																																																						
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																						
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																						
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																						
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																						
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																						
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																						
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																						
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																						
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																						
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																						
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																						
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																						
6	2011	ALL	Chassis	Electronic Brake Control Module																																																						
6	2011	ALL	Body	Body Control Module																														V																								
6	2011	ALL	Body	Digital Radio Receiver																																																						
6	2011	ALL	Body	Generator Battery Control Module																																																						
6	2011	ALL	Body	Instrument Panel Cluster																																																						
6	2011	ALL	Body	Passenger Presence System																																																						
6	2011	ALL	Body	Personal Audio Link Module																																																						
6	2011	ALL	Body	Base Radio																																																						

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
6	2011	ALL	Body	Uplevel Radio																																																								
6	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
6	2011	ALL	Body	Theft Deterrent Module																																																							
6	2011	ALL	Body	Vehicle Comm. Interface Module																																	V		V																				
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																						
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																						
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																						
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																						
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																						
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																						
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																						
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																						
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																						
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																						
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																						
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																						
6	2012	ALL	Chassis	Electronic Brake Control Module																																																						
6	2012	ALL	Body	Body Control Module																														V																									
6	2012	ALL	Body	Digital Radio Receiver																																																					
6	2012	ALL	Body	Generator Battery Control Module																																																					
6	2012	ALL	Body	Instrument Panel Cluster																																																					
6	2012	ALL	Body	Passenger Presence System																																																					
6	2012	ALL	Body	Personal Audio Link Module																																																					
6	2012	ALL	Body	Base Radio																																																					
6	2012	ALL	Body	Uplevel Radio																																																					
6	2012	ALL	Body	Supplemental Inflatable Restraint																																																					
6	2012	ALL	Body	Theft Deterrent Module																																																					
6	2012	ALL	Body	Vehicle Comm. Interface Module																																	V		V																			
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																		
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																					
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																					
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																				V																																		
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																					
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																					
6	2015	Canyon	Powertrain	Chassis Control Module																																																		V	V		
6	2015	Canyon	Powertrain	Transfer Case Control Module																																																					
6	2015	Canyon	Chassis	Electronic Brake Control Module					V																																																
6	2015	Canyon	Chassis	Power Steering Control Module				V	V																																																
6	2015	Canyon	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																								V					
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																				V	V				V	V	V	V	V	V																							
6	2015	Canyon	Body	Passenger Presence Module																															V																						
6	2015	Canyon	Body	Radio																																																				
6	2015	Canyon	Body	Amplifier																																																				
6	2015	Canyon	Body	Human Machine Interface Control Module																																																				
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																	V	V	V																		
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																														V											V	V	V	V							
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																														V											V	V	V	V							
6	2015	Canyon	Body	Parking Assist Control Module																																V																				
6	2015	Canyon	Body	Frontview Camera Module																																																				
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																				V																																		
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																					

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																				V																																						
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
6	2016	Canyon	Powertrain	Transfer Case Control Module																																																										
6	2016	Canyon	Chassis	Electronic Brake Control Module					V																																																				
6	2016	Canyon	Chassis	Power Steering Control Module				V	V																																																				
6	2016	Canyon	Body	Body Control Module						V	V	V		V	V			V	V		V	V	V	V	V		V	V																									V							
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V	V																										
6	2016	Canyon	Body	Passenger Presence Module																																V																										
6	2016	Canyon	Body	Trailer Interface Control Module																																	V																								
6	2016	Canyon	Body	Radio																																																									
6	2016	Canyon	Body	Amplifier																																																									
6	2016	Canyon	Body	Human Machine Interface Control Module																																																									
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																	V	V	V																						
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																														V													V	V	V	V									
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																														V													V	V	V	V									
6	2016	Canyon	Body	Frontview Camera Module																																																									
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2011	Express/Savana	Body	Body Control Module																																																									
7	2011	Express/Savana	Body	Digital Radio Receiver																																																									
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																									
7	2011	Express/Savana	Body	Passenger Presence System																																																									
7	2011	Express/Savana	Body	Radio																																																									
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
7	2011	Express/Savana	Body	Rollover Sensor																																																									
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
7	2011	Express/Savana	Body	Theft Deterrent Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2011	Express Access/Savana Pro	Body	Body Control Module																																																												
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																												
7	2011	Express Access/Savana Pro	Body	Radio																																																												
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																												
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2012	Express/Savana	Body	Body Control Module																																																												
7	2012	Express/Savana	Body	Digital Radio Receiver																																																												
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																												
7	2012	Express/Savana	Body	Passenger Presence System																																																												
7	2012	Express/Savana	Body	Radio																																																												
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
7	2012	Express/Savana	Body	Rollover Sensor																																																												
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
7	2012	Express/Savana	Body	Theft Deterrent Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																									
7	2012	Express Access/Savana Pro	Body	Radio																																																									
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																									
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2013	Express/Savana	Body	Body Control Module																																																									
7	2013	Express/Savana	Body	Digital Radio Receiver																																																									
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																									
7	2013	Express/Savana	Body	Passenger Presence System																																																									
7	2013	Express/Savana	Body	Radio																																																									
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
7	2013	Express/Savana	Body	Rollover Sensor																																																									
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
7	2013	Express/Savana	Body	Theft Deterrent Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2013	Express Access/Savana Pro	Body	Body Control Module																																																										
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																									
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																									
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																									
7	2013	Express Access/Savana Pro	Body	Radio																																																									
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																									
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																									
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																									
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																				V																																				
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																									
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																				V																																				
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																									
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																									
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
7	2014	Savana	Chassis	Electronic Brake Control Module																																																									
7	2014	Savana	Body	Body Control Module						V	V	V						V					V	V																																					
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V			V	V																										
7	2014	Savana	Body	Passenger Presence Module																										V																														
7	2014	Savana	Body	Rollover Sensor Module																																																									
7	2014	Savana	Body	Instrument Cluster																																																									
7	2014	Savana	Body	Chime Alarm Control Module																																																									
7	2014	Savana	Body	Base Radio																																																									
7	2014	Savana	Body	Navigation Radio																																																									
7	2014	Savana	Body	Uplevel Radio																																																									
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																									
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																				
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																				

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
7	2014	Savana	Body	Auxiliary Heater Control Module																																																								
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																									
7	2014	Savana	Body	Parking Assist Control Module																																V																									
7	2014	Savana	Body	Theft Deterrent Module										V																																														
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																				V																																					
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																					
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																					
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
7	2015	Savana	Chassis	Electronic Brake Control Module																																																									
7	2015	Savana	Body	Body Control Module						V	V	V						V					V	V																																					
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V			V	V																											
7	2015	Savana	Body	Rollover Sensor Module																																																									
7	2015	Savana	Body	Instrument Cluster																																																									
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																									
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																	V	V	V	V																				
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																	V	V	V																				
7	2015	Savana	Body	Auxiliary Heater Control Module																																																									
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																									
7	2015	Savana	Body	Parking Assist Control Module																																V																									
7	2015	Savana	Body	Theft Deterrent Module										V																																														
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																				V																																					
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																					
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																					
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
7	2016	Savana	Chassis	Electronic Brake Control Module																																																									
7	2016	Savana	Body	Body Control Module						V	V	V						V					V	V																																					
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																											
7	2016	Savana	Body	Instrument Cluster																																																									
7	2016	Savana	Body	Chime Alarm Control Module																																																									
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																									
7	2016	Savana	Body	Telematics Communication Interface Control Module																																	V	V	V																					
7	2016	Savana	Body	Auxiliary Heater Control Module																																																									
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																									
7	2016	Savana	Body	Parking Assist Control Module																																V																									
7	2016	Savana	Body	Theft Deterrent Module										V																																														
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2011	Express/Savana	Body	Body Control Module																																																										
8	2011	Express/Savana	Body	Digital Radio Receiver																																																										
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
8	2011	Express/Savana	Body	Passenger Presence System																																																										
8	2011	Express/Savana	Body	Radio																																																										
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
8	2011	Express/Savana	Body	Rollover Sensor																																																										
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
8	2011	Express/Savana	Body	Theft Deterrent Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2011	Express Access/Savana Pro	Body	Body Control Module																																																										
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																										
8	2011	Express Access/Savana Pro	Body	Radio																																																										
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																										
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2012	Express/Savana	Body	Body Control Module																																																										
8	2012	Express/Savana	Body	Digital Radio Receiver																																																										
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																										
8	2012	Express/Savana	Body	Passenger Presence System																																																										
8	2012	Express/Savana	Body	Radio																																																										
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																										

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
8	2012	Express/Savana	Body	Rollover Sensor																																																									
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
8	2012	Express/Savana	Body	Theft Deterrent Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																									
8	2012	Express Access/Savana Pro	Body	Radio																																																									
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																									
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2013	Express/Savana	Body	Body Control Module																																																									
8	2013	Express/Savana	Body	Digital Radio Receiver																																																									
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																									
8	2013	Express/Savana	Body	Navigation Radio																																																									
8	2013	Express/Savana	Body	Park Assist Module																																																									
8	2013	Express/Savana	Body	Passenger Presence System																																																									
8	2013	Express/Savana	Body	Radio																																																									
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
8	2013	Express/Savana	Body	Rollover Sensor																																																									
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
8	2013	Express/Savana	Body	Theft Deterrent Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
8	2013	Express Access/Savana Pro	Body	Body Control Module																																																								
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																								
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																																								
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																								
8	2013	Express Access/Savana Pro	Body	Radio																																																								
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																								
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																								
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																								
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																				V																																				
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																								
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																				V																																				
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																								
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																								
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
8	2014	Savana	Chassis	Electronic Brake Control Module																																																								
8	2014	Savana	Body	Body Control Module						V	V	V						V					V	V																																				
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V			V	V																										
8	2014	Savana	Body	Passenger Presence Module																										V																														
8	2014	Savana	Body	Rollover Sensor Module																																																								
8	2014	Savana	Body	Instrument Cluster																																																								
8	2014	Savana	Body	Chime Alarm Control Module																																																								
8	2014	Savana	Body	Base Radio																																																								
8	2014	Savana	Body	Navigation Radio																																																								
8	2014	Savana	Body	Uplevel Radio																																																								
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																								
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																					
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																						
8	2014	Savana	Body	Auxiliary Heater Control Module																																																								
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																								
8	2014	Savana	Body	Parking Assist Control Module																															V																									
8	2014	Savana	Body	Theft Deterrent Module										V																																														
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																				V																																				
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																				
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																				
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																							
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																							
8	2015	Savana	Chassis	Electronic Brake Control Module																																																							
8	2015	Savana	Body	Body Control Module						V	V	V						V					V	V																																			
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V			V	V																									
8	2015	Savana	Body	Rollover Sensor Module																																																							
8	2015	Savana	Body	Instrument Cluster																																																							
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																							
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																V	V	V	V																			
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																V	V	V																			
8	2015	Savana	Body	Auxiliary Heater Control Module																																																							
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																							
8	2015	Savana	Body	Parking Assist Control Module																																V																						
8	2015	Savana	Body	Theft Deterrent Module										V																																													
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																				V																																			
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																							
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																				V																																			
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																							
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																				V																																			
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																							
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																							
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																							
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																							
8	2016	Savana	Chassis	Electronic Brake Control Module																																																							
8	2016	Savana	Body	Body Control Module						V	V	V						V					V	V																																			
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																									V	V	V	V	V	V																									
8	2016	Savana	Body	Instrument Cluster																																																							
8	2016	Savana	Body	Chime Alarm Control Module																																																							
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																							
8	2016	Savana	Body	Telematics Communication Interface Control Module																																V	V	V																				
8	2016	Savana	Body	Auxiliary Heater Control Module																																																							
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																							
8	2016	Savana	Body	Parking Assist Control Module																																V																						
8	2016	Savana	Body	Theft Deterrent Module										V																																													
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																							
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																							
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																							
ALL	2004	ALL	Chassis	ABS																																																							
ALL	2004	ALL	Chassis	Air Suspension																																																							
ALL	2004	ALL	Body	Amplifier (Bose)																																																							
ALL	2004	ALL	Body	Body Control Module																														V																									
ALL	2004	ALL	Body	Digital Radio Receiver																																																							
ALL	2004	ALL	Body	Driver Door Module																																																							
ALL	2004	ALL	Body	Driver Seat Module																																																							
ALL	2004	ALL	Body	Heating and Air Conditioning																																																							
ALL	2004	ALL	Body	Instrument Panel Cluster																																																							
ALL	2004	ALL	Body	OnStar																																V																						
ALL	2004	ALL	Body	Passenger Door Module																																																							

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
ALL	2004	ALL	Body	Uplevel Radio																																																									
ALL	2004	ALL	Body	Navigation Radio																																																									
ALL	2004	ALL	Body	Rear Seat Audio																																																									
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																									
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									
ALL	2005	ALL	Chassis	ABS																																																									
ALL	2005	ALL	Chassis	Air Suspension																																																									
ALL	2005	ALL	Body	Body Control Module																														V																												
ALL	2005	ALL	Body	Digital Radio Receiver																																																									
ALL	2005	ALL	Body	Driver Door Module (SUV)																																																									
ALL	2005	ALL	Body	Driver Door Module (SUT)																																																									
ALL	2005	ALL	Body	Driver Seat Module																																																									
ALL	2005	ALL	Body	Heating and Air Conditioning																																																									
ALL	2005	ALL	Body	Instrument Panel Cluster																																																									
ALL	2005	ALL	Body	Passenger Door Module																																																									
ALL	2005	ALL	Body	Uplevel Radio																																																									
ALL	2005	ALL	Body	Navigation Radio																																																									
ALL	2005	ALL	Body	Rear Seat Audio																																																									
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																									
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									
ALL	2006	H2	Chassis	ABS																																																									
ALL	2006	H2	Chassis	Air Suspension																																																									
ALL	2006	H2	Body	Body Control Module																														V																												
ALL	2006	H2	Body	Digital Radio Receiver																																																									
ALL	2006	H2	Body	Driver Door Module (SUV)																																																									
ALL	2006	H2	Body	Driver Door Module (SUT)																																																									
ALL	2006	H2	Body	Driver Seat Module																																																									
ALL	2006	H2	Body	Heating and Air Conditioning																																																									
ALL	2006	H2	Body	Instrument Panel Cluster																																																									
ALL	2006	H2	Body	Passenger Door Module																																																									
ALL	2006	H2	Body	Uplevel Radio																																																									
ALL	2006	H2	Body	Navigation Radio																																																									
ALL	2006	H2	Body	Rear Seat Audio																																																									
ALL	2006	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2006	H3	Powertrain	Engine Control Module																																																									
ALL	2006	H3	Powertrain	Transmission Control Module																																																									
ALL	2006	H3	Powertrain	Transfer Case Control Module																																																									
ALL	2006	H3	Chassis	Antilock Brake System																																																									
ALL	2006	H3	Body	Body Control Module																														V																												
ALL	2006	H3	Body	Digital Radio Receiver																																																									
ALL	2006	H3	Body	Instrument Panel Cluster																																																									
ALL	2006	H3	Body	Uplevel Radio																																																									
ALL	2006	H3	Body	Navigation Radio																																																									
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																																									
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																									
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
ALL	2007	H2	Chassis	ABS																																																									
ALL	2007	H2	Chassis	Air Suspension																																																									
ALL	2007	H2	Body	Amplifier (Bose)																																																									
ALL	2007	H2	Body	Body Control Module																														V																												
ALL	2007	H2	Body	Digital Radio Receiver																																																									
ALL	2007	H2	Body	Driver Door Module (SUV)																																																									
ALL	2007	H2	Body	Driver Door Module (SUT)																																																									
ALL	2007	H2	Body	Driver Seat Module																																																									
ALL	2007	H2	Body	HVAC Control Module																																																									
ALL	2007	H2	Body	Instrument Panel Cluster																																																									
ALL	2007	H2	Body	Passenger Door Module																																																									
ALL	2007	H2	Body	Uplevel Radio																																																									
ALL	2007	H2	Body	Navigation Radio																																																									
ALL	2007	H2	Body	Rear Seat Audio																																																									
ALL	2007	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																V																										
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																									
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																									
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																									
ALL	2007	H3	Chassis	EBCM																																																									
ALL	2007	H3	Body	Body Control Module (5GT)																														V																												
ALL	2007	H3	Body	Body Control Module (ADM)																														V																												
ALL	2007	H3	Body	Digital Radio Receiver																																																									
ALL	2007	H3	Body	Generator Battery Control Module																																																									
ALL	2007	H3	Body	Instrument Panel Cluster																																																									
ALL	2007	H3	Body	Personal Audio Link Module																																																									
ALL	2007	H3	Body	Uplevel Radio																																																									
ALL	2007	H3	Body	Navigation Radio																																																									
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																																									
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																V																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																									
ALL	2008	H2	Chassis	Air SCM																																																									
ALL	2008	H2	Chassis	EBCM																																																									
ALL	2008	H2	Body	Amplifier (Bose)																																																									
ALL	2008	H2	Body	Body Control Module																																																									
ALL	2008	H2	Body	Digital Radio Receiver																																																									
ALL	2008	H2	Body	Driver Door Switch																																																									
ALL	2008	H2	Body	HVAC Control Module																																											V														
ALL	2008	H2	Body	Instrument Panel Cluster																																																									
ALL	2008	H2	Body	Memory Seat Module																																																									
ALL	2008	H2	Body	Passenger Door Switch																																																									
ALL	2008	H2	Body	Radio																																																									
ALL	2008	H2	Body	Rear Heated Seat Module																																																									
ALL	2008	H2	Body	Rear HVAC/RSA																																																									
ALL	2008	H2	Body	Rollover Sensor																																																									
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2008	H2	Body	Theft Deterrent Module																																																									
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)																																																									
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																																										
ALL	2008	H3	Chassis	EBCM																																																										
ALL	2008	H3	Body	Body Control Module (5GT)																														V																												
ALL	2008	H3	Body	Body Control Module (ADM)																														V																												
ALL	2008	H3	Body	Digital Radio Receiver																																																									
ALL	2008	H3	Body	Generator Battery Control Module																																																									
ALL	2008	H3	Body	Instrument Panel Cluster																																																									
ALL	2008	H3	Body	Personal Audio Link Module																																																									
ALL	2008	H3	Body	Uplevel Radio																																																									
ALL	2008	H3	Body	Navigation Radio																																																									
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																																									
ALL	2008	H3	Body	Theft Deterrent Module																																																									
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																	V																								
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																									
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																									
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																									
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																									
ALL	2009	H2	Chassis	Air SCM																																																									
ALL	2009	H2	Chassis	EBCM																																																									
ALL	2009	H2	Body	Amplifier (Bose)																																																									
ALL	2009	H2	Body	Body Control Module																																																									
ALL	2009	H2	Body	Digital Radio Receiver																																																									
ALL	2009	H2	Body	Driver Door Switch																																																									
ALL	2009	H2	Body	HVAC Control Module																																											V														
ALL	2009	H2	Body	Instrument Panel Cluster																																																									
ALL	2009	H2	Body	Memory Seat Module																																																									
ALL	2009	H2	Body	Passenger Door Switch																																																									
ALL	2009	H2	Body	Radio																																																									
ALL	2009	H2	Body	Rear Heated Seat Module																																																									
ALL	2009	H2	Body	Rear HVAC/RSA																																																									
ALL	2009	H2	Body	Rollover Sensor																																																									
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2009	H2	Body	Theft Deterrent Module																																																									
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																	V																								
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																	V		V																						
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)																																																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																									
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)																																																									
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)																																																									
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																									
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																																									
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																																									
ALL	2009	H3	Chassis	EBCM																																																									
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																														V																												
ALL	2009	H3	Body	Body Control Module (ADM)																														V																												
ALL	2009	H3	Body	Digital Radio Receiver																																																									
ALL	2009	H3	Body	Generator Battery Control Module																																																									
ALL	2009	H3	Body	Instrument Panel Cluster																																																									
ALL	2009	H3	Body	Personal Audio Link Module																																																									
ALL	2009	H3	Body	Uplevel Radio																																																									
ALL	2009	H3	Body	Navigation Radio																																																									
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																																									
ALL	2009	H3	Body	Theft Deterrent Module																																																									
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																	V		V																						
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																									
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																									
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																									
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																									
ALL	2010	H2	Chassis	Air SCM																																																									
ALL	2010	H2	Chassis	EBCM																																																									
ALL	2010	H2	Body	Amplifier (Bose)																																																									
ALL	2010	H2	Body	Body Control Module																																																									
ALL	2010	H2	Body	Digital Radio Receiver																																																									
ALL	2010	H2	Body	Driver Door Switch																																																									
ALL	2010	H2	Body	HVAC Control Module																																												V													
ALL	2010	H2	Body	Instrument Panel Cluster																																																									
ALL	2010	H2	Body	Memory Seat Module																																																									
ALL	2010	H2	Body	Passenger Door Switch																																																									
ALL	2010	H2	Body	Personal Audio Link Module																																																									
ALL	2010	H2	Body	Radio																																																									
ALL	2010	H2	Body	Rear Heated Seat Module																																																									
ALL	2010	H2	Body	Rear HVAC/RSA																																																									
ALL	2010	H2	Body	Rollover Sensor																																																									
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2010	H2	Body	Theft Deterrent Module																																																									
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																	V		V																						
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																									
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																									
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																									
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																									
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																									
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module																																																									
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																									
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																																									
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																																									
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																																									
ALL	2010	H3	Chassis	EBCM																																																									
ALL	2010	H3	Body	Body Control Module																														V																												
ALL	2010	H3	Body	Digital Radio Receiver																																																									
ALL	2010	H3	Body	Generator Battery Control Module																																																									
ALL	2010	H3	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	Power Steering Softstops Reset	Power Steering Softstops Learn	Steering Wheel Angle Sensor Centering	Steering Wheel Angle Sensor Reset	Steering Wheel Angle Sensor Learn	Chassis Control Data	Content Theft Deterrent Alarm Trigger Data	Electric Power Management Data	Exterior Lighting 1 Data	Immobilizer Data	Interior Lighting 1 Data	Interior Lighting 2 Data	Keyless Entry Data	Power Mode Data	Remote Function Actuator Data	Sunroof Data	Vehicle Access Data	Windows Data	Wiper/Washer Data	Brake Pedal Position Sensor Learn	Clear Driver Window Learned Values	Clear Passenger Window Learned Values	Read LIN Bus Device ID Information	Tire Pressure Sensors Learn	SDM Data	Primary Key Data	Deployment Loop 1-14 Resistance Data	Deployment Loop 15-18 Resistance Data	Deployment Loop Configuration Data	Sensor Configuration Data	Security Data	Passenger Presence Sensor Learn	CAN Bus Configuration Learn	GPS Data	Signal Strength Data	Bluetooth Data	DTC B1000 Information	Driver Seat Heating/Venting/Cooling Data	Passenger Seat Heating/Venting/Cooling Data	Left Rear Seat Heating/Venting/Cooling Data	Right Rear Seat Heating/Venting/Cooling Data	Object Detection History Data	Object Detection Sensor Data	HVAC Sensor Data	HVAC System Data	HVAC Door Position Data 1	HVAC Faceplate Data	HVAC Actuators Learn	Secondary Air Injection Data	Tire Pressure Monitoring System Data	Gear Selector -N- Position Learn	Learned Values Reset	Active Grille Air Shutter Data	Active Grille Air Shutter System	14V Power Module	Autostart/Autostop
ALL	2010	H3	Body	Personal Audio Link Module																																																												
ALL	2010	H3	Body	Uplevel Radio																																																												
ALL	2010	H3	Body	Navigation Radio																																																												
ALL	2010	H3	Body	Supplemental Inflatable Restraint																																																												
ALL	2010	H3	Body	Theft Deterrent Module																																																												
ALL	2010	H3	Body	Vehicle Comm. Interface Module																																	V		V																									

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2007	Yukon	Body	Assist Step Controller																																																													
C	2007	Yukon	Body	Body Control Module																																																													
C	2007	Yukon	Body	Body Control Module (aux.)																																																													
C	2007	Yukon	Body	Digital Radio Receiver																																																													
C	2007	Yukon	Body	Driver Door Switch																																																													
C	2007	Yukon	Body	HVAC Control Module Auto																																																													
C	2007	Yukon	Body	HVAC Control Module Manual																																																													
C	2007	Yukon	Body	Instrument Panel Cluster																																																													
C	2007	Yukon	Body	Lift Gate Module																																																													
C	2007	Yukon	Body	Memory Seat Module																																																													
C	2007	Yukon	Body	Park Assist Module																																																													
C	2007	Yukon	Body	Passenger Door Switch																																																													
C	2007	Yukon	Body	Passenger Presence System																																																													
C	2007	Yukon	Body	Radio																																																													
C	2007	Yukon	Body	Rear Heated Seat Module																																																													
C	2007	Yukon	Body	Rear HVAC/RSA																																																													
C	2007	Yukon	Body	Rollover Sensor																																																													
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																																													
C	2007	Yukon	Body	Theft Deterrent Module																																																													
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																													
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																													
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																													
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																													
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																													
C	2007	Yukon XL	Body	Amplifier (Bose)																																																													
C	2007	Yukon XL	Body	Assist Step Controller																																																													
C	2007	Yukon XL	Body	Body Control Module																																																													
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																													
C	2007	Yukon XL	Body	Digital Radio Receiver																																																													
C	2007	Yukon XL	Body	Driver Door Switch																																																													
C	2007	Yukon XL	Body	HVAC Control Module Auto																																																													
C	2007	Yukon XL	Body	HVAC Control Module Manual																																																													
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																													
C	2007	Yukon XL	Body	Lift Gate Module																																																													
C	2007	Yukon XL	Body	Memory Seat Module																																																													
C	2007	Yukon XL	Body	Park Assist Module																																																													
C	2007	Yukon XL	Body	Passenger Door Switch																																																													
C	2007	Yukon XL	Body	Passenger Presence System																																																													
C	2007	Yukon XL	Body	Radio																																																													

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																												
C	2008	Yukon Hybrid	Body	Body Control Module																																																												
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																												
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																												
C	2008	Yukon Hybrid	Body	HVAC Control Module																																																												
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
C	2008	Yukon Hybrid	Body	Lift Gate Module																																																												
C	2008	Yukon Hybrid	Body	Memory Seat Module																																																												
C	2008	Yukon Hybrid	Body	Park Assist Module																																																												
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																												
C	2008	Yukon Hybrid	Body	Passenger Presence System																																																												
C	2008	Yukon Hybrid	Body	Radio																																																												
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																												
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon XL	Body	Amplifier (Bose)																																																												
C	2008	Yukon XL	Body	Assist Step Controller																																																												
C	2008	Yukon XL	Body	Body Control Module																																																												
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2008	Yukon XL	Body	Digital Radio Receiver																																																												
C	2008	Yukon XL	Body	Driver Door Switch																																																												
C	2008	Yukon XL	Body	HVAC Control Module Auto																																																												
C	2008	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2008	Yukon XL	Body	Lift Gate Module																																																												
C	2008	Yukon XL	Body	Memory Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2008	Yukon XL	Body	Park Assist Module																																																													
C	2008	Yukon XL	Body	Passenger Door Switch																																																													
C	2008	Yukon XL	Body	Passenger Presence System																																																													
C	2008	Yukon XL	Body	Radio																																																													
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																													
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																													
C	2008	Yukon XL	Body	Rollover Sensor																																																													
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																													
C	2008	Yukon XL	Body	Theft Deterrent Module																																																													
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																													
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																													
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																													
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																													
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																													
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual																																																													
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																													
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																													
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													
C	2009	Sierra	Chassis	Electronic Suspension Control																																																													
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																													
C	2009	Sierra	Body	Amplifier (Bose)																																																													
C	2009	Sierra	Body	Body Control Module																																																													
C	2009	Sierra	Body	Body Control Module (aux.)																																																													
C	2009	Sierra	Body	Digital Radio Receiver																																																													
C	2009	Sierra	Body	Driver Door Switch																																																													
C	2009	Sierra	Body	HVAC Control Module Auto																																																													

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed																																																														
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed																																																														
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																														
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																														
C	2009	Yukon	Chassis	Electronic Brake Control Module																																																														
C	2009	Yukon	Chassis	Electronic Suspension Control																																																														
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																														
C	2009	Yukon	Body	Amplifier (Bose)																																																														
C	2009	Yukon	Body	Assist Step Controller																																																														
C	2009	Yukon	Body	Body Control Module																																																														
C	2009	Yukon	Body	Body Control Module (aux.)																																																														
C	2009	Yukon	Body	Digital Radio Receiver																																																														
C	2009	Yukon	Body	Driver Door Switch																																																														
C	2009	Yukon	Body	HVAC Control Module Auto																																																														
C	2009	Yukon	Body	HVAC Control Module Manual																																																														
C	2009	Yukon	Body	Instrument Panel Cluster																																																														
C	2009	Yukon	Body	Left Side Object Detection Module																																																														
C	2009	Yukon	Body	Lift Gate Module																																																														
C	2009	Yukon	Body	Memory Seat Module																																																														
C	2009	Yukon	Body	Park Assist Module																																																														
C	2009	Yukon	Body	Passenger Door Switch																																																														
C	2009	Yukon	Body	Passenger Presence System																																																														
C	2009	Yukon	Body	Radio																																																														
C	2009	Yukon	Body	Rear Heated Seat Module																																																														
C	2009	Yukon	Body	Rear HVAC/RSA																																																														
C	2009	Yukon	Body	Right Side Object Detection Module																																																														
C	2009	Yukon	Body	Rollover Sensor																																																														
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																																														
C	2009	Yukon	Body	Theft Deterrent Module																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module				V		V																																																							
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																														
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																														
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																														
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																														
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																														
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																														
C	2009	Yukon Hybrid	Body	Body Control Module																																																														

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																										
G	2004	Express/Savana	Body	Body Control Module																																																										
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2004	Express/Savana	Body	OnStar																																																										
G	2004	Express/Savana	Body	Base Radio																																																										
G	2004	Express/Savana	Body	Uplevel Radio																																																										
G	2004	Express/Savana	Body	Remote Function Actuation																																																										
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																																										
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																												
G	2006	Express/Savana	Chassis	VSES																																																												
G	2006	Express/Savana	Body	Body Control Module																																																												
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																												
G	2006	Express/Savana	Body	Passenger Presence System																																																												
G	2006	Express/Savana	Body	Base Radio																																																												
G	2006	Express/Savana	Body	Uplevel Radio																																																												
G	2006	Express/Savana	Body	Remote Function Actuation																																																												
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
G	2006	Express Access/Savana Pro	Chassis	VSES																																																												
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2006	Express Access/Savana Pro	Body	Base Radio																																																												
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																												
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
H	2007	Express/Savana	Body	Uplevel Radio																																																												
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																													
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2007	Express Access/Savana Pro	Body	Base Radio																																																												
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2008	Express/Savana	Body	Body Control Module																																																												
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2008	Express/Savana	Body	Passenger Presence System																																																												
H	2008	Express/Savana	Body	Radio																																																												
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2008	Express/Savana	Body	Rollover Sensor																																																												
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2008	Express/Savana	Body	Theft Deterrent Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2007	Sierra	Chassis	Electronic Suspension Control																																																													
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																													
K	2007	Sierra	Body	Amplifier (Bose)																																																													
K	2007	Sierra	Body	Body Control Module																																																													
K	2007	Sierra	Body	Body Control Module (aux.)																																																													
K	2007	Sierra	Body	Digital Radio Receiver																																																													
K	2007	Sierra	Body	Driver Door Switch																																																													
K	2007	Sierra	Body	HVAC Control Module Auto																																																													
K	2007	Sierra	Body	HVAC Control Module Manual																																																													
K	2007	Sierra	Body	Instrument Panel Cluster																																																													
K	2007	Sierra	Body	Memory Seat Module																																																													
K	2007	Sierra	Body	Park Assist Module																																																													
K	2007	Sierra	Body	Passenger Door Switch																																																													
K	2007	Sierra	Body	Passenger Presence System																																																													
K	2007	Sierra	Body	Radio																																																													
K	2007	Sierra	Body	Rear Heated Seat Module																																																													
K	2007	Sierra	Body	Rear HVAC/RSA																																																													
K	2007	Sierra	Body	Rollover Sensor																																																													
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																																													
K	2007	Sierra	Body	Theft Deterrent Module																																																													
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																													
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																													
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																													
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2007	Yukon	Chassis	Electronic Suspension Control																																																													
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																													
K	2007	Yukon	Body	Amplifier (Bose)																																																													
K	2007	Yukon	Body	Assist Step Controller																																																													
K	2007	Yukon	Body	Body Control Module																																																													
K	2007	Yukon	Body	Body Control Module (aux.)																																																													
K	2007	Yukon	Body	Digital Radio Receiver																																																													
K	2007	Yukon	Body	Driver Door Switch																																																													
K	2007	Yukon	Body	HVAC Control Module Auto																																																													
K	2007	Yukon	Body	HVAC Control Module Manual																																																													
K	2007	Yukon	Body	Instrument Panel Cluster																																																													
K	2007	Yukon	Body	Lift Gate Module																																																													
K	2007	Yukon	Body	Memory Seat Module																																																													
K	2007	Yukon	Body	Park Assist Module																																																													

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2007	Yukon	Body	Passenger Door Switch																																																												
K	2007	Yukon	Body	Passenger Presence System																																																												
K	2007	Yukon	Body	Radio																																																											
K	2007	Yukon	Body	Rear Heated Seat Module																																																											
K	2007	Yukon	Body	Rear HVAC/RSA																																																											
K	2007	Yukon	Body	Rollover Sensor																																																											
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																																											
K	2007	Yukon	Body	Theft Deterrent Module																																																											
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																											
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																											
K	2007	Yukon XL	Body	Amplifier (Bose)																																																											
K	2007	Yukon XL	Body	Assist Step Controller																																																											
K	2007	Yukon XL	Body	Body Control Module																																																											
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																											
K	2007	Yukon XL	Body	Digital Radio Receiver																																																											
K	2007	Yukon XL	Body	Driver Door Switch																																																											
K	2007	Yukon XL	Body	HVAC Control Module Auto																																																											
K	2007	Yukon XL	Body	HVAC Control Module Manual																																																											
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																											
K	2007	Yukon XL	Body	Lift Gate Module																																																											
K	2007	Yukon XL	Body	Memory Seat Module																																																											
K	2007	Yukon XL	Body	Park Assist Module																																																											
K	2007	Yukon XL	Body	Passenger Door Switch																																																											
K	2007	Yukon XL	Body	Passenger Presence System																																																											
K	2007	Yukon XL	Body	Radio																																																										
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																											
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																											
K	2007	Yukon XL	Body	Rollover Sensor																																																											
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
K	2007	Yukon XL	Body	Theft Deterrent Module																																																											
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module				V		V																																																						
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																												
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Sierra Hybrid	Body	Body Control Module																																																												
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																												
K	2010	Sierra Hybrid	Body	Driver Door Switch																																																												
K	2010	Sierra Hybrid	Body	Heated Seat Module																																																												
K	2010	Sierra Hybrid	Body	HVAC Control Module																																																												
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
K	2010	Sierra Hybrid	Body	Park Assist Module																																																												
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																																												
K	2010	Sierra Hybrid	Body	Passenger Presence System																																																												
K	2010	Sierra Hybrid	Body	Radio																																																												
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																												
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																												
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon	Chassis	Electronic Brake Control Module																																																												
K	2010	Yukon	Chassis	Electronic Suspension Control																																																												
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon	Body	Amplifier (Bose)																																																												
K	2010	Yukon	Body	Assist Step Controller																																																												
K	2010	Yukon	Body	Body Control Module																																																												
K	2010	Yukon	Body	Body Control Module (aux.)																																																												
K	2010	Yukon	Body	Digital Radio Receiver																																																												
K	2010	Yukon	Body	Driver Door Switch																																																												
K	2010	Yukon	Body	HVAC Control Module Auto																																																												
K	2010	Yukon	Body	HVAC Control Module Manual																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
R	2014	Acadia	Body	Liftgate Control Module																																																													
R	2014	Acadia	Body	Seat Memory Control Module																																																													
R	2014	Acadia	Body	Front Seat Heating Control Module																																																													
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																													
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																													
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																													
R	2014	Acadia	Body	Parking Assist Control Module																																																													
R	2014	Acadia	Body	Frontview Camera Module																											V	V																																	
R	2014	Acadia	Body	Theft Deterrent Module																																																													
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																													
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																													
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																													
R	2015	Acadia	Chassis	Electronic Brake Control Module											V	V	V	V	V																																														
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate		V															V																					V																						
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)		V															V																					V																						
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
R	2015	Acadia	Body	Passenger Presence Module																																																													
R	2015	Acadia	Body	Instrument Cluster																																																													
R	2015	Acadia	Body	Head-Up Display Module																																																													
R	2015	Acadia	Body	Radio																																																												
R	2015	Acadia	Body	Rear Audio Control Module																																																												
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																												
R	2015	Acadia	Body	Personal Audio Link Control Module																																																												
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																												
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																												
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																												
R	2015	Acadia	Body	Liftgate Control Module																																																												
R	2015	Acadia	Body	Seat Memory Control Module																																																												
R	2015	Acadia	Body	Front Seat Heating Control Module																																																												
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																												
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																												
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																												
R	2015	Acadia	Body	Parking Assist Control Module																																																												
R	2015	Acadia	Body	Frontview Camera Module																											V	V																																	
R	2015	Acadia	Body	Theft Deterrent Module																																																													
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
R	2016	Acadia	Chassis	Electronic Brake Control Module											V	V	V	V	V																																													
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate		V															V																					V																						
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)		V															V																					V																						
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2016	Acadia	Body	Passenger Presence Module																																																												
R	2016	Acadia	Body	Instrument Cluster																																																												
R	2016	Acadia	Body	Head-Up Display Module																																																												
R	2016	Acadia	Body	Radio																																																											
R	2016	Acadia	Body	Rear Audio Control Module																																																											
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
R	2016	Acadia	Body	Personal Audio Link Control Module																																																												
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																												
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																												
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																												
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																												
R	2016	Acadia	Body	Liftgate Control Module																																																												
R	2016	Acadia	Body	Seat Memory Control Module																																																												
R	2016	Acadia	Body	Front Seat Heating Control Module																																																												
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																												
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																												
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																												
R	2016	Acadia	Body	Parking Assist Control Module																																																												
R	2016	Acadia	Body	Frontview Camera Module																											V	V																																
R	2016	Acadia	Body	Theft Deterrent Module																																																												
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																												
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																												
S	2004	Sonoma	Body	Body Control Module																																																												
S	2004	Sonoma	Body	Instrument Panel Cluster																																																												
S	2004	Sonoma	Body	Base Radio																																																												
S	2004	Sonoma	Body	Uplevel Radio																																																												
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																												
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
S	2004	Canyon	Chassis	ABS Without Traction Control																																																												
S	2004	Canyon	Chassis	ABS With Traction Control																																																												
S	2004	Canyon	Body	Body Control Module																																																												
S	2004	Canyon	Body	Instrument Panel Cluster																																																												
S	2004	Canyon	Body	OnStar																																																												
S	2004	Canyon	Body	Base Radio																																																												
S	2004	Canyon	Body	Uplevel Radio																																																												
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																																												
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	Envoy	Chassis	ABS Without Traction Control																																																												
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																												
S	2004	Envoy	Body	Amplifier (Bose)																																																												
S	2004	Envoy	Body	Body Control Module																																																												
S	2004	Envoy	Body	Driver Door Module																																																												
S	2004	Envoy	Body	Driver Seat Module																																																												
S	2004	Envoy	Body	Heating and Air Conditioning Auto																																																												
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																												
S	2004	Envoy	Body	Instrument Panel Cluster																																																												
S	2004	Envoy	Body	Lift Gate Module																																																												
S	2004	Envoy	Body	OnStar																																																												
S	2004	Envoy	Body	Passenger Door Module																																																												

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
S	2004	Envoy	Body	Uplevel Radio																																																												
S	2004	Envoy	Body	Navigation Radio																																																												
S	2004	Envoy	Body	Rear Seat Audio																																																												
S	2004	Envoy	Body	Rear Seat Entertainment																																																												
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2004	Envoy	Body	Vehicle Theft Deterrent																																																												
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																												
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																												
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																												
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																												
S	2004	Envoy XL	Body	Amplifier (Bose)																																																												
S	2004	Envoy XL	Body	Body Control Module																																																												
S	2004	Envoy XL	Body	Driver Door Module																																																												
S	2004	Envoy XL	Body	Driver Seat Module																																																												
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																												
S	2004	Envoy XL	Body	Lift Gate Module																																																												
S	2004	Envoy XL	Body	OnStar																																																												
S	2004	Envoy XL	Body	Passenger Door Module																																																												
S	2004	Envoy XL	Body	Uplevel Radio																																																												
S	2004	Envoy XL	Body	Navigation Radio																																																												
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
S	2004	Envoy XL	Body	Rear HVAC Manual																																																												
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																												
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																												
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																												
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																												
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																												
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																												
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																												
S	2004	Envoy XUV	Body	Body Control Module																																																												
S	2004	Envoy XUV	Body	Driver Door Module																																																												
S	2004	Envoy XUV	Body	Driver Seat Module																																																												
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																												
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																												
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																												
S	2004	Envoy XUV	Body	Lift Gate Module																																																												
S	2004	Envoy XUV	Body	OnStar																																																												
S	2004	Envoy XUV	Body	Passenger Door Module																																																												
S	2004	Envoy XUV	Body	Uplevel Radio																																																												
S	2004	Envoy XUV	Body	Navigation Radio																																																												
S	2004	Envoy XUV	Body	Rear Seat Audio																																																												
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
T	2009	Canyon	Body	Digital Radio Receiver																																																													
T	2009	Canyon	Body	Generator Battery Control Module																																																													
T	2009	Canyon	Body	Instrument Panel Cluster																																																													
T	2009	Canyon	Body	Passenger Presence System																																																													
T	2009	Canyon	Body	Base Radio																																																													
T	2009	Canyon	Body	Uplevel Radio																																																													
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																																													
T	2009	Canyon	Body	Theft Deterrent Module																																																													
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																													
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																													
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																													
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																													
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																													
T	2009	Envoy	Body	Body Control Module																																																													
T	2009	Envoy	Body	Digital Radio Receiver																																																													
T	2009	Envoy	Body	Disc Player and Video Display																																																													
T	2009	Envoy	Body	Driver Door Module																																																													
T	2009	Envoy	Body	Driver Seat Module																																																													
T	2009	Envoy	Body	Generator Battery Control Module																																																													
T	2009	Envoy	Body	HVAC Control Module Auto																																																													
T	2009	Envoy	Body	HVAC Control Module Manual																																																													
T	2009	Envoy	Body	Instrument Panel Cluster																																																													
T	2009	Envoy	Body	Lift Gate Module																																																													
T	2009	Envoy	Body	Passenger Door Module																																																													
T	2009	Envoy	Body	Passenger Presence System																																																													
T	2009	Envoy	Body	Uplevel Radio																																																													
T	2009	Envoy	Body	Navigation Radio																																																													
T	2009	Envoy	Body	Rear Seat Audio																																																													
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																																													
T	2009	Envoy	Body	Theft Deterrent Module																																																													
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																													
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																													
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																													
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																													
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																													
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																													
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																													
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																													
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																													
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																													
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																													
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																													
T	2010	ALL	Chassis	Electronic Brake Control Module																																																													
T	2010	ALL	Body	Body Control Module																																																													
T	2010	ALL	Body	Digital Radio Receiver																																																													
T	2010	ALL	Body	Generator Battery Control Module																																																													
T	2010	ALL	Body	Instrument Panel Cluster																																																													

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
T	2010	ALL	Body	Passenger Presence System																																																													
T	2010	ALL	Body	Personal Audio Link Module																																																													
T	2010	ALL	Body	Base Radio																																																												
T	2010	ALL	Body	Uplevel Radio																																																												
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2010	ALL	Body	Theft Deterrent Module																																																												
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																												
V	2007	ALL	Powertrain	Engine Control Module																																																												
V	2007	ALL	Powertrain	Rear Drive System																																																												
V	2007	ALL	Powertrain	Transmission Control Module																																																												
V	2007	ALL	Chassis	Electronic Brake Control Module																																																												
V	2007	ALL	Body	Body Control Module																																																												
V	2007	ALL	Body	Digital Radio Receiver																																																												
V	2007	ALL	Body	Driver Door Switch																																																												
V	2007	ALL	Body	Head Up Display																																																												
V	2007	ALL	Body	Heated Seat Module																																																												
V	2007	ALL	Body	HVAC Control Module Auto																																																												
V	2007	ALL	Body	HVAC Control Module Manual																																																												
V	2007	ALL	Body	Instrument Panel Cluster																																																												
V	2007	ALL	Body	Lift Gate Module																																																												
V	2007	ALL	Body	Park Assist Module																																																												
V	2007	ALL	Body	Passenger Door Switch																																																												
V	2007	ALL	Body	Passenger Presence System																																																												
V	2007	ALL	Body	Radio																																																												
V	2007	ALL	Body	Rear HVAC/RSA																																																												
V	2007	ALL	Body	Rollover Sensor																																																												
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2007	ALL	Body	Theft Deterrent Module																																																												
V	2008	ALL	Powertrain	Engine Control Module																																																												
V	2008	ALL	Powertrain	Rear Drive System																																																												
V	2008	ALL	Powertrain	Transmission Control Module																																																												
V	2008	ALL	Chassis	Electronic Brake Control Module																																																												
V	2008	ALL	Body	Body Control Module																																																												
V	2008	ALL	Body	Digital Radio Receiver																																																												
V	2008	ALL	Body	Driver Door Switch																																																												
V	2008	ALL	Body	Head Up Display																																																												
V	2008	ALL	Body	Heated Seat Module																																																												
V	2008	ALL	Body	HVAC Control Module Auto																																																												
V	2008	ALL	Body	HVAC Control Module Manual																																																												
V	2008	ALL	Body	Instrument Panel Cluster																																																												
V	2008	ALL	Body	Lift Gate Module																																																												
V	2008	ALL	Body	Park Assist Module																																																												
V	2008	ALL	Body	Passenger Door Switch																																																												
V	2008	ALL	Body	Passenger Presence System																																																												
V	2008	ALL	Body	Radio																																																												
V	2008	ALL	Body	Rear HVAC/RSA																																																												
V	2008	ALL	Body	Rollover Sensor																																																												
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2008	ALL	Body	Theft Deterrent Module																																																												
V	2009	ALL	Powertrain	Engine Control Module																																																												
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																										
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
V	2015	Acadia	Body	Liftgate Control Module																																																										
V	2015	Acadia	Body	Seat Memory Control Module																																																										
V	2015	Acadia	Body	Front Seat Heating Control Module																																																										
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																										
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																										
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																										
V	2015	Acadia	Body	Parking Assist Control Module																																																										
V	2015	Acadia	Body	Frontview Camera Module																											V	V																														
V	2015	Acadia	Body	Theft Deterrent Module																																																										
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Acadia	Chassis	Electronic Brake Control Module											V	V	V	V	V																																											
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate		V															V																					V																				
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)		V															V																					V																				
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Acadia	Body	Passenger Presence Module																																																										
V	2016	Acadia	Body	Instrument Cluster																																																										
V	2016	Acadia	Body	Head-Up Display Module																																																										
V	2016	Acadia	Body	Radio																																																										
V	2016	Acadia	Body	Rear Audio Control Module																																																										
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																										
V	2016	Acadia	Body	Personal Audio Link Control Module																																																										
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																										
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Acadia	Body	Liftgate Control Module																																																										
V	2016	Acadia	Body	Seat Memory Control Module																																																										
V	2016	Acadia	Body	Front Seat Heating Control Module																																																										
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																										
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																										
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																										
V	2016	Acadia	Body	Parking Assist Control Module																																																										
V	2016	Acadia	Body	Frontview Camera Module																											V	V																														
V	2016	Acadia	Body	Theft Deterrent Module																																																										
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																													
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																													
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																													
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																												
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																												
1	2011	Yukon Hybrid	Body	Body Control Module																																																												
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																												
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																												
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																												
1	2011	Yukon Hybrid	Body	HVAC Control Module																																																												
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
1	2011	Yukon Hybrid	Body	Lift Gate Module																																																												
1	2011	Yukon Hybrid	Body	Park Assist Module																																																												
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																												
1	2011	Yukon Hybrid	Body	Passenger Presence System																																																												
1	2011	Yukon Hybrid	Body	Radio																																																												
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																												
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																												
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																												
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
1	2011	Yukon XL	Body	Amplifier (Bose)																																																												
1	2011	Yukon XL	Body	Assist Step Controller																																																												
1	2011	Yukon XL	Body	Body Control Module																																																												
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																												
1	2011	Yukon XL	Body	Digital Radio Receiver																																																												
1	2011	Yukon XL	Body	Driver Door Switch																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																												
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon XL	Body	Amplifier (Bose)																																																												
1	2013	Yukon XL	Body	Assist Step Controller																																																											
1	2013	Yukon XL	Body	Body Control Module																																																											
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																											
1	2013	Yukon XL	Body	Digital Radio Receiver																																																											
1	2013	Yukon XL	Body	Driver Door Switch																																																											
1	2013	Yukon XL	Body	HVAC Control Module Auto																																																											
1	2013	Yukon XL	Body	HVAC Control Module Manual																																																											
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																											
1	2013	Yukon XL	Body	Left Side Object Detection Module																																																											
1	2013	Yukon XL	Body	Lift Gate Module																																																											
1	2013	Yukon XL	Body	Memory Seat Module																																																											
1	2013	Yukon XL	Body	Park Assist Module																																																											
1	2013	Yukon XL	Body	Passenger Door Switch																																																											
1	2013	Yukon XL	Body	Passenger Presence System																																																											
1	2013	Yukon XL	Body	Radio																																																											
1	2013	Yukon XL	Body	Navigation Radio																																																											
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																											
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																											
1	2013	Yukon XL	Body	Right Side Object Detection Module																																																											
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
1	2013	Yukon XL	Body	Theft Deterrent Module																																																											
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																											
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2014	Sierra	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																													
1	2014	Sierra	Chassis	Parking Brake Control Module																																																												
1	2014	Sierra	Chassis	Power Steering Control Module																			V													V																											
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Sierra	Body	Body Control Module																	V																																										
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	Sierra	Body	Passenger Presence Module																																																											
1	2014	Sierra	Body	Instrument Cluster																																																											
1	2014	Sierra	Body	Radio Control																																																											
1	2014	Sierra	Body	HVAC Control																																																											
1	2014	Sierra	Body	Radio																		V	V																																							
1	2014	Sierra	Body	Amplifier																				V	V																																					

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	Sierra	Body	Passenger Presence Module																																																												
1	2015	Sierra	Body	Instrument Cluster																																																												
1	2015	Sierra	Body	Radio Controls																																																												
1	2015	Sierra	Body	HVAC Controls																																																												
1	2015	Sierra	Body	Radio																		V	V																																								
1	2015	Sierra	Body	Amplifier																				V	V																																							
1	2015	Sierra	Body	Media Disc Player																																																												
1	2015	Sierra	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																		
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																												
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																												
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
1	2015	Sierra	Body	Parking Assist Control Module																																																												
1	2015	Sierra	Body	Frontview Camera Module																											V	V																																
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																												
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																												
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																												
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																												
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																												
1	2015	Yukon	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																													
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																V																																											
1	2015	Yukon	Chassis	Parking Brake Control Module																																																												
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2015	Yukon	Chassis	Power Steering Control Module																			V													V																											
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2015	Yukon	Chassis	Suspension Control Module																																																												
1	2015	Yukon	Body	Body Control Module																	V																																											
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2015	Yukon	Body	Passenger Presence Module																																																												
1	2015	Yukon	Body	Instrument Cluster																																																												
1	2015	Yukon	Body	Radio Controls																																																												
1	2015	Yukon	Body	HVAC Controls																																																												
1	2015	Yukon	Body	Radio																		V	V																																								
1	2015	Yukon	Body	Amplifier																				V	V																																							
1	2015	Yukon	Body	Media Disc Player																																																												
1	2015	Yukon	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																		
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																												
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																												
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
1	2016	Sierra	Body	Frontview Camera Module																											V	V																														
1	2016	Sierra	Body	Frontview Camera Module																											V	V																														
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2016	Yukon	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																											
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																V																																									
1	2016	Yukon	Chassis	Parking Brake Control Module																																																										
1	2016	Yukon	Chassis	Power Steering Control Module																			V													V																										
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2016	Yukon	Chassis	Suspension Control Module																																																									
1	2016	Yukon	Body	Body Control Module																																																									
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2016	Yukon	Body	Passenger Presence Module																																																									
1	2016	Yukon	Body	Instrument Cluster																																																									
1	2016	Yukon	Body	Radio Controls																																																									
1	2016	Yukon	Body	HVAC Controls																																																									
1	2016	Yukon	Body	Radio																		V	V																																						
1	2016	Yukon	Body	Amplifier																				V	V																																			
1	2016	Yukon	Body	Media Disc Player																																																									
1	2016	Yukon	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																									
1	2016	Yukon	Body	HVAC Control Module																																																									
1	2016	Yukon	Body	Liftgate Control Module																																																									
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																									
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																									
1	2016	Yukon	Body	Keyless Entry Control Module																																																									
1	2016	Yukon	Body	Assist Step Control Module																																																									
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																									
1	2016	Yukon	Body	Parking Assist Control Module																																																									
1	2016	Yukon	Body	Frontview Camera Module																											V	V																														
1	2016	Yukon	Body	Steering Column Lock Control Module																																																									
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2016	Yukon XL	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																											
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																V																																									
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2016	Yukon XL	Chassis	Power Steering Control Module																			V													V																										
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2016	Yukon XL	Chassis	Suspension Control Module																																																									
1	2016	Yukon XL	Body	Body Control Module																																																									
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
2	2013	Yukon XL	Body	Radio																																																												
2	2013	Yukon XL	Body	Navigation Radio																																																												
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																												
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																												
2	2013	Yukon XL	Body	Right Side Object Detection Module																																																												
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
2	2013	Yukon XL	Body	Theft Deterrent Module																																																												
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																												
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2014	Sierra	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																													
2	2014	Sierra	Chassis	Parking Brake Control Module																																																												
2	2014	Sierra	Chassis	Power Steering Control Module																			V														V																											
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2014	Sierra	Body	Body Control Module																	V																																											
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2014	Sierra	Body	Passenger Presence Module																																																												
2	2014	Sierra	Body	Instrument Cluster																																																												
2	2014	Sierra	Body	Radio Control																																																												
2	2014	Sierra	Body	HVAC Control																																																												
2	2014	Sierra	Body	Radio																		V	V																																									
2	2014	Sierra	Body	Amplifier																				V	V																																							
2	2014	Sierra	Body	Media Disc Player																																																												
2	2014	Sierra	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																		
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																												
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
2	2014	Sierra	Body	Parking Assist Control Module																																																												
2	2014	Sierra	Body	Frontview Camera Module																											V	V																																
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																												
2	2014	Sierra HD	Chassis	Electronic Brake Control Module											V	V	V	V																																														
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																												
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2015	Sierra	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																													
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																V																																												
2	2015	Sierra	Chassis	Power Steering Control Module																			V													V																												
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2015	Sierra	Chassis	Suspension Control Module																																													V															
2	2015	Sierra	Body	Body Control Module																																																												
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2015	Sierra	Body	Passenger Presence Module																																																												
2	2015	Sierra	Body	Instrument Cluster																																																												
2	2015	Sierra	Body	Radio Controls																																																												
2	2015	Sierra	Body	HVAC Controls																																																												
2	2015	Sierra	Body	Radio																		V	V																																									
2	2015	Sierra	Body	Amplifier																				V	V																																							
2	2015	Sierra	Body	Media Disc Player																																																												
2	2015	Sierra	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																		
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																												
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																												
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
2	2015	Sierra	Body	Parking Assist Control Module																																																												
2	2015	Sierra	Body	Frontview Camera Module																											V	V																																
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2016	Sierra	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																													
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																V																																											
2	2016	Sierra	Chassis	Parking Brake Control Module																																																												
2	2016	Sierra	Chassis	Power Steering Control Module																																																											
2	2016	Sierra	Chassis	Power Steering Control Module																			V														V																										
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2016	Sierra	Chassis	Suspension Control Module																																																											
2	2016	Sierra	Body	Body Control Module									V																																																	
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2016	Sierra	Body	Passenger Presence Module																																																											
2	2016	Sierra	Body	Instrument Cluster																																																											
2	2016	Sierra	Body	Radio Controls																																																										
2	2016	Sierra	Body	HVAC Controls																																																										
2	2016	Sierra	Body	Radio (IO3)																		V	V																																							
2	2016	Sierra	Body	Radio (IOB)																																																										
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																		V	V																																						
2	2016	Sierra	Body	Amplifier																				V	V																																				
2	2016	Sierra	Body	Media Disc Player																																																									
2	2016	Sierra	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																															
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																									
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																									
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																									
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																									
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																									
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																									
2	2016	Sierra	Body	Parking Assist Control Module																																																									
2	2016	Sierra	Body	Frontview Camera Module																											V	V																												
2	2016	Sierra	Body	Frontview Camera Module																											V	V																												
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2016	Yukon	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																												
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																V																																											
2	2016	Yukon	Chassis	Parking Brake Control Module																																																											
2	2016	Yukon	Chassis	Power Steering Control Module																			V														V																										
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2016	Yukon	Chassis	Suspension Control Module																																																											
2	2016	Yukon	Body	Body Control Module																																																											
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2016	Yukon	Body	Passenger Presence Module																																																											
2	2016	Yukon	Body	Instrument Cluster																																																											
2	2016	Yukon	Body	Radio Controls																																																											
2	2016	Yukon	Body	HVAC Controls																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
2	2016	Yukon	Body	Radio																		V	V																																								
2	2016	Yukon	Body	Amplifier																				V	V																																						
2	2016	Yukon	Body	Media Disc Player																																																											
2	2016	Yukon	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																	
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																										
2	2016	Yukon	Body	HVAC Control Module																																																										
2	2016	Yukon	Body	Liftgate Control Module																																																										
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																										
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																										
2	2016	Yukon	Body	Keyless Entry Control Module																																																										
2	2016	Yukon	Body	Assist Step Control Module																																																										
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																										
2	2016	Yukon	Body	Parking Assist Control Module																																																										
2	2016	Yukon	Body	Frontview Camera Module																											V	V																															
2	2016	Yukon	Body	Steering Column Lock Control Module																																																										
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2016	Yukon XL	Chassis	Electronic Brake Control Module										V	V	V	V	V	V																																												
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																V																																											
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																											
2	2016	Yukon XL	Chassis	Power Steering Control Module																			V														V																										
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2016	Yukon XL	Chassis	Suspension Control Module																																																											
2	2016	Yukon XL	Body	Body Control Module																																																											
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2016	Yukon XL	Body	Passenger Presence Module																																																											
2	2016	Yukon XL	Body	Instrument Cluster																																																											
2	2016	Yukon XL	Body	Radio Controls																																																											
2	2016	Yukon XL	Body	HVAC Controls																																																											
2	2016	Yukon XL	Body	Radio																		V	V																																								
2	2016	Yukon XL	Body	Amplifier																				V	V																																						
2	2016	Yukon XL	Body	Media Disc Player																																																											
2	2016	Yukon XL	Body	Human Machine Interface Control Module																			V			V	V	V	V	V																																	
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																										
2	2016	Yukon XL	Body	HVAC Control Module																																																											
2	2016	Yukon XL	Body	Liftgate Control Module																																																											
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																										
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																										
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																										
2	2016	Yukon XL	Body	Assist Step Control Module																																																										
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																										
2	2016	Yukon XL	Body	Parking Assist Control Module																																																										
2	2016	Yukon XL	Body	Frontview Camera Module																											V	V																															
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																										
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																														
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																														
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																														
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																															
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module								V																																																					
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																														
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																														
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																														
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																														
7	2011	Express Access/Savana Pro	Body	Body Control Module																																																														
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																														
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																														
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																														
7	2011	Express Access/Savana Pro	Body	Radio																																																														
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																														
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																														
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																														
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																														
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																														
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																														
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																														
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																														
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																														
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module								V																																																					
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																														
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																														
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																														
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																														
7	2012	Express/Savana	Body	Body Control Module																																																														
7	2012	Express/Savana	Body	Digital Radio Receiver																																																														
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																														
7	2012	Express/Savana	Body	Passenger Presence System																																																														
7	2012	Express/Savana	Body	Radio																																																														
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																														
7	2012	Express/Savana	Body	Rollover Sensor																																																														
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																														
7	2012	Express/Savana	Body	Theft Deterrent Module																																																														
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																														

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module								V																																																				
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2013	Express Access/Savana Pro	Body	Body Control Module																																																												
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																												
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																												
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																												
7	2013	Express Access/Savana Pro	Body	Radio																																																												
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																												
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																												
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
7	2014	Savana	Chassis	Electronic Brake Control Module										V	V	V	V																																															
7	2014	Savana	Body	Body Control Module		V														V																					V																							
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
7	2014	Savana	Body	Passenger Presence Module																																																												
7	2014	Savana	Body	Rollover Sensor Module																																																												
7	2014	Savana	Body	Instrument Cluster																																																												
7	2014	Savana	Body	Chime Alarm Control Module																																																												
7	2014	Savana	Body	Base Radio																																																												
7	2014	Savana	Body	Navigation Radio																																																												
7	2014	Savana	Body	Uplevel Radio																																																												
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																												
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																												
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
7	2014	Savana	Body	Auxiliary Heater Control Module		V																																																											
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																												
7	2014	Savana	Body	Parking Assist Control Module																																																												
7	2014	Savana	Body	Theft Deterrent Module																																																												
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
7	2015	Savana	Chassis	Electronic Brake Control Module											V	V	V	V																																														
7	2015	Savana	Body	Body Control Module		V															V																					V																						
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
7	2015	Savana	Body	Rollover Sensor Module																																																												
7	2015	Savana	Body	Instrument Cluster																																																												
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																											
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											
7	2015	Savana	Body	Auxiliary Heater Control Module		V																																																										
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																											
7	2015	Savana	Body	Parking Assist Control Module																																																											
7	2015	Savana	Body	Theft Deterrent Module																																																											
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
7	2016	Savana	Chassis	Electronic Brake Control Module											V	V	V	V																																													
7	2016	Savana	Body	Body Control Module		V															V																					V																						
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
7	2016	Savana	Body	Instrument Cluster																																																											
7	2016	Savana	Body	Chime Alarm Control Module																																																											
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																											
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																											
7	2016	Savana	Body	Auxiliary Heater Control Module		V																																																									
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																											
7	2016	Savana	Body	Parking Assist Control Module																																																											
7	2016	Savana	Body	Theft Deterrent Module																																																											
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2011	Express/Savana	Body	Body Control Module																																																												
8	2011	Express/Savana	Body	Digital Radio Receiver																																																												
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																												
8	2011	Express/Savana	Body	Passenger Presence System																																																												
8	2011	Express/Savana	Body	Radio																																																												
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
8	2011	Express/Savana	Body	Rollover Sensor																																																												
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
8	2011	Express/Savana	Body	Theft Deterrent Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2011	Express Access/Savana Pro	Body	Body Control Module																																																												
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																												
8	2011	Express Access/Savana Pro	Body	Radio																																																												
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																												
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2012	Express/Savana	Body	Body Control Module																																																												
8	2012	Express/Savana	Body	Digital Radio Receiver																																																												
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																												
8	2012	Express/Savana	Body	Passenger Presence System																																																												
8	2012	Express/Savana	Body	Radio																																																												
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																												

Engine type	Year	Model	System 1	System 2	Auxiliary Transmission Fluid Pump	Brake Pedal Position Data	Hybrid/EV Data	Voltage Data	Hybrid/EV Battery Voltage Leveling Data	Temperature Data	Fuel Rail Pressure Relief Valve Learned Values Reset	Fuel Injector Data	Tire Pressure Sensor Signal Reset	Adaptive Pressure Control Data	Traction Control Left Front Solenoid Valves	Traction Control Right Front Solenoid Valves	Traction Control Left Rear Solenoid Valves	Traction Control Right Rear Solenoid Valves	Brake Pressure Sensor Calibration	Distance Sensing Cruise Control Module	Interior Lighting Data	Erase Valet Mode Code	Control Module Reset	Data Analysis 1	Data Analysis 2	Bluetooth Device 1 Data	Bluetooth Device 2 Data	WLAN Device Data	Info Display Test	Speech Recognition	Clear Disable History Data	Frontview Camera Learn	Clutch pedal position learn	Fuel Pump Trim Reset	Headlamp Leveling Sensor Learn	Neutral Position Sensor Learn	Clear Active Pull Compensation Learned Limits	Clear Left Rear Window Learned Values	Clear Right Rear Window Learned Values	Actuator Data	Folding Top Data	Exterior Lighting Data	Park Assist System Data	Park Assist Disable History 1-4 Data	Park Assist Disable History 5-7 Data	Fuel Pump Control Module Data	Engine Mount Data	Transfer Case Clutch Overtemperature Counter Reset	Suspension Position Sensor Trim Height	Distance Sensing Cruise Control Inhibit History 1 Data	Distance Sensing Cruise Control Disengage History 1 Data	Distance Sensing Cruise Control Inhibit History 2 Data	Distance Sensing Cruise Control Disengage History 2 Data	Distance Sensing Cruise Control Inhibit History 3 Data	Distance Sensing Cruise Control Disengage History 3 Data	Distance Sensing Cruise Control Inhibit History 4 Data	Distance Sensing Cruise Control Disengage History 4 Data	Distance Sensing Cruise Control Inhibit History 5 Data	Distance Sensing Cruise Control Disengage History 5 Data	Distance Sensing Cruise Control Inhibit History 6 Data
8	2012	Express/Savana	Body	Rollover Sensor																																																													
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
8	2012	Express/Savana	Body	Theft Deterrent Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2012	Express Access/Savana Pro	Body	Body Control Module																																																												
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																												
8	2012	Express Access/Savana Pro	Body	Radio																																																												
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																												
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2013	Express/Savana	Body	Body Control Module																																																												
8	2013	Express/Savana	Body	Digital Radio Receiver																																																												
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																												
8	2013	Express/Savana	Body	Navigation Radio																																																												
8	2013	Express/Savana	Body	Park Assist Module																																																												
8	2013	Express/Savana	Body	Passenger Presence System																																																												
8	2013	Express/Savana	Body	Radio																																																												
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
8	2013	Express/Savana	Body	Rollover Sensor																																																												
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
8	2013	Express/Savana	Body	Theft Deterrent Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

| Engine type | Year | Model | System 1 | System 2 | Auxiliary Transmission Fluid Pump | Brake Pedal Position Data | Hybrid/EV Data | Voltage Data | Hybrid/EV Battery Voltage Leveling Data | Temperature Data | Fuel Rail Pressure Relief Valve Learned Values Reset | Fuel Injector Data | Tire Pressure Sensor Signal Reset | Adaptive Pressure Control Data | Traction Control Left Front Solenoid Valves | Traction Control Right Front Solenoid Valves | Traction Control Left Rear Solenoid Valves | Traction Control Right Rear Solenoid Valves | Brake Pressure Sensor Calibration | Distance Sensing Cruise Control Module | Interior Lighting Data | Erase Valet Mode Code | Control Module Reset | Data Analysis 1 | Data Analysis 2 | Bluetooth Device 1 Data | Bluetooth Device 2 Data | WLAN Device Data | Info Display Test | Speech Recognition | Clear Disable History Data | Frontview Camera Learn | Clutch pedal position learn | Fuel Pump Trim Reset | Headlamp Leveling Sensor Learn | Neutral Position Sensor Learn | Clear Active Pull Compensation Learned Limits | Clear Left Rear Window Learned Values | Clear Right Rear Window Learned Values | Actuator Data | Folding Top Data | Exterior Lighting Data | Park Assist System Data | Park Assist Disable History 1-4 Data | Park Assist Disable History 5-7 Data | Fuel Pump Control Module Data | Engine Mount Data | Transfer Case Clutch Overtemperature Counter Reset | Suspension Position Sensor Trim Height | Distance Sensing Cruise Control Inhibit History 1 Data | Distance Sensing Cruise Control Disengage History 1 Data | Distance Sensing Cruise Control Inhibit History 2 Data | Distance Sensing Cruise Control Disengage History 2 Data | Distance Sensing Cruise Control Inhibit History 3 Data | Distance Sensing Cruise Control Disengage History 3 Data | Distance Sensing Cruise Control Inhibit History 4 Data | Distance Sensing Cruise Control Disengage History 4 Data | Distance Sensing Cruise Control Inhibit History 5 Data | Distance Sensing Cruise Control Disengage History 5 Data | Distance Sensing Cruise Control Inhibit History 6 Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM													V	V																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																							
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																						
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																						
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																V	V	V		V	V	V																																
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																								
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																								
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																								
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module													V	V																																								
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																V	V	V		V	V	V																																
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module													V	V																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																V	V	V		V	V	V																																
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																V	V	V		V	V	V																																
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module													V	V																																								
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																				V	V	V	V	V																														
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																								
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																				V	V	V	V	V																														
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module													V	V																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																V	V	V		V	V	V																																
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																				V	V	V	V	V																														
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																						
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																						
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																						
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																						
C	2004	ALL	Chassis	ESC																																																						
C	2004	ALL	Chassis	Rear Wheel Steering																																																						
C	2004	ALL	Chassis	Tire Pressure Monitor																																																						
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																						
C	2004	ALL	Chassis	VSES																																																						
C	2004	ALL	Body	Amplifier (Bose)																																																						
C	2004	ALL	Body	Body Control Module																																					V	V	V																
C	2004	ALL	Body	CD Changer																																																						
C	2004	ALL	Body	Chime																																																						
C	2004	ALL	Body	Driver Door Module																																					V	V	V																
C	2004	ALL	Body	Driver Seat Module																																																						
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																						
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																						
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																						
C	2004	ALL	Body	Instrument Panel Cluster																																																						
C	2004	ALL	Body	OnStar																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2004	ALL	Body	Passenger Door Module																																						V	V	V																
C	2004	ALL	Body	Passenger Presence System																																																							
C	2004	ALL	Body	Radio Base																																																							
C	2004	ALL	Body	Radio Uplevel																																																							
C	2004	ALL	Body	Radio Navigation																																																							
C	2004	ALL	Body	Rear Aux. Climate Module																																						V																		
C	2004	ALL	Body	Rear HVAC																																																							
C	2004	ALL	Body	Rear Seat Audio																																						V																		
C	2004	ALL	Body	Rear Seat Entertainment																																																							
C	2004	ALL	Body	Supplemental Inflatable Restraint																																						V	V																		
C	2004	ALL	Body	Vehicle Theft Deterrent																																						V																		
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM													V	V																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																							
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																							
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																							
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																V	V	V		V	V	V																																	
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																	
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																	
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																	
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																	
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																V	V	V		V	V	V																																	
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																	
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																	
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																V	V	V		V	V	V																																	
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																V	V	V		V	V	V																																	
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																	
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																				V	V	V	V	V																															
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module													V	V																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																V	V	V		V	V	V																																	
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																				V	V	V	V	V																															
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																							
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																							
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																							
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																							
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																							
C	2005	ALL	Chassis	ESC																																																							
C	2005	ALL	Chassis	Rear Wheel Steering																																																							
C	2005	ALL	Chassis	Tire Pressure Monitor																																																							
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																							
C	2005	ALL	Chassis	VSES																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2005	ALL	Body	Amplifier (Bose)																																																								
C	2005	ALL	Body	Body Control Module																																					V	V	V																	
C	2005	ALL	Body	CD Changer																																																								
C	2005	ALL	Body	Chime																																																								
C	2005	ALL	Body	Disc Player and Video Display																																																								
C	2005	ALL	Body	Driver Door Module																																					V	V	V																	
C	2005	ALL	Body	Driver Seat Module																																																								
C	2005	ALL	Body	Generator Battery Control Module																																																								
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																								
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																								
C	2005	ALL	Body	Instrument Panel Cluster																																																								
C	2005	ALL	Body	Passenger Door Module																																					V	V	V																	
C	2005	ALL	Body	Passenger Presence System																																																								
C	2005	ALL	Body	Base Radio																																																								
C	2005	ALL	Body	Uplevel Radio																																																								
C	2005	ALL	Body	Navigation Radio																																																								
C	2005	ALL	Body	Rear Aux. Climate Module																																					V																			
C	2005	ALL	Body	Rear HVAC																																																								
C	2005	ALL	Body	Rear Seat Audio																																					V																			
C	2005	ALL	Body	Supplemental Inflatable Restraint																																					V																			V
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																								
C	2005	ALL	Body	Vehicle Theft Deterrent																																					V																			
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM													V	V																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																V	V	V		V	V	V																																		
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																		
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																		
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																		
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module													V	V																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																V	V	V		V	V	V																																		
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																		
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																		
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module													V	V																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module													V	V																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																V	V	V		V	V	V																																		
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																V	V	V		V	V	V																																		
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																		
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module													V	V																																										
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																				V	V	V	V	V																																
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																											
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																				V	V	V	V	V																																
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module													V	V																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																				V	V	V	V	V																																
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																V	V	V		V	V	V																																		
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																								
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																								
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																								
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
C	2006	ALL	Chassis	ESC																																																								
C	2006	ALL	Chassis	Tire Pressure Monitor																																																								
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																								
C	2006	ALL	Chassis	VSES																																																								
C	2006	ALL	Body	Amplifier (Bose)																																																								
C	2006	ALL	Body	Body Control Module																																					V	V	V																		
C	2006	ALL	Body	CD Changer																																																								
C	2006	ALL	Body	Chime																																																								
C	2006	ALL	Body	Disc Player and Video Display																																																								
C	2006	ALL	Body	Driver Door Module																																					V	V	V																		
C	2006	ALL	Body	Driver Seat Module																																																								
C	2006	ALL	Body	Generator Battery Control Module																																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																								
C	2006	ALL	Body	Instrument Panel Cluster																																																								
C	2006	ALL	Body	Passenger Door Module																																					V	V	V																		
C	2006	ALL	Body	Passenger Presence System																																																								
C	2006	ALL	Body	Base Radio																																																								
C	2006	ALL	Body	Uplevel Radio																																																								
C	2006	ALL	Body	Navigation Radio																																																								
C	2006	ALL	Body	Rear Aux. Climate Module																																					V																				
C	2006	ALL	Body	Rear HVAC																																																								
C	2006	ALL	Body	Rear Seat Audio																																					V																				
C	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																				V
C	2006	ALL	Body	Vehicle Theft Deterrent																																					V																				
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																								
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																										V		V	V																												
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V													V																								
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																										V		V	V																												
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																								
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																										V		V	V																												
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																								
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																										V		V	V																												
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																							
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																										V		V	V																												
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																										
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																								
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																										
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																						
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																										
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																								
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																								
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2007	Sierra	Chassis	Electronic Suspension Control																																																								
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																								
C	2007	Sierra	Body	Amplifier (Bose)																																																								
C	2007	Sierra	Body	Body Control Module			V																																			V	V																	
C	2007	Sierra	Body	Body Control Module (aux.)																																																								
C	2007	Sierra	Body	Digital Radio Receiver																																																								
C	2007	Sierra	Body	Driver Door Switch																																					V	V	V																	
C	2007	Sierra	Body	HVAC Control Module Auto																																						V		V																
C	2007	Sierra	Body	HVAC Control Module Manual																																						V		V																
C	2007	Sierra	Body	Instrument Panel Cluster																																																							
C	2007	Sierra	Body	Memory Seat Module																																																							
C	2007	Sierra	Body	Park Assist Module																																																							
C	2007	Sierra	Body	Passenger Door Switch																																					V	V	V																	
C	2007	Sierra	Body	Passenger Presence System																																					V																		
C	2007	Sierra	Body	Radio																																																							
C	2007	Sierra	Body	Rear Heated Seat Module																																																								
C	2007	Sierra	Body	Rear HVAC/RSA																																																								
C	2007	Sierra	Body	Rollover Sensor																																																							
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																					V																			
C	2007	Sierra	Body	Theft Deterrent Module																																																								
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																										
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																								
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																								
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																								
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																										
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																						
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2007	Yukon	Chassis	Electronic Suspension Control																																																								
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																								
C	2007	Yukon	Body	Amplifier (Bose)																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2007	Yukon	Body	Assist Step Controller																																																								
C	2007	Yukon	Body	Body Control Module			V																																			V	V																	
C	2007	Yukon	Body	Body Control Module (aux.)																																																								
C	2007	Yukon	Body	Digital Radio Receiver																																																								
C	2007	Yukon	Body	Driver Door Switch																																					V	V	V																	
C	2007	Yukon	Body	HVAC Control Module Auto																																						V		V																
C	2007	Yukon	Body	HVAC Control Module Manual																																						V		V																
C	2007	Yukon	Body	Instrument Panel Cluster																																																								
C	2007	Yukon	Body	Lift Gate Module																																					V																			
C	2007	Yukon	Body	Memory Seat Module																																																								
C	2007	Yukon	Body	Park Assist Module																																																								
C	2007	Yukon	Body	Passenger Door Switch																																					V	V	V																	
C	2007	Yukon	Body	Passenger Presence System																																					V																			
C	2007	Yukon	Body	Radio																																																								
C	2007	Yukon	Body	Rear Heated Seat Module																																																								
C	2007	Yukon	Body	Rear HVAC/RSA																																																								
C	2007	Yukon	Body	Rollover Sensor																																																								
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																					V																			
C	2007	Yukon	Body	Theft Deterrent Module																																																								
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																										
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																							
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																										
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																		
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																							
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																										
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																						
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																							
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																							
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																								
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																								
C	2007	Yukon XL	Body	Amplifier (Bose)																																																								
C	2007	Yukon XL	Body	Assist Step Controller																																																								
C	2007	Yukon XL	Body	Body Control Module			V																																			V	V																	
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																								
C	2007	Yukon XL	Body	Digital Radio Receiver																																																								
C	2007	Yukon XL	Body	Driver Door Switch																																					V	V	V																	
C	2007	Yukon XL	Body	HVAC Control Module Auto																																						V		V																
C	2007	Yukon XL	Body	HVAC Control Module Manual																																						V		V																
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																								
C	2007	Yukon XL	Body	Lift Gate Module																																					V																			
C	2007	Yukon XL	Body	Memory Seat Module																																																								
C	2007	Yukon XL	Body	Park Assist Module																																																								
C	2007	Yukon XL	Body	Passenger Door Switch																																					V	V	V																	
C	2007	Yukon XL	Body	Passenger Presence System																																					V																			
C	2007	Yukon XL	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2007	Yukon XL	Body	Rear Heated Seat Module																																																									
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2007	Yukon XL	Body	Rollover Sensor																																																										
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																				V																						
C	2007	Yukon XL	Body	Theft Deterrent Module																																																										
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																													
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																										
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																															
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V													V																										
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																													
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																										
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																													
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																									
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																													
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																										
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																													
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																										
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																													
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																									
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																													
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																		
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																													
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																										
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																													
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																										
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																			V																						
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2008	Sierra	Chassis	Electronic Suspension Control																																																									
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																									
C	2008	Sierra	Body	Amplifier (Bose)																																																									
C	2008	Sierra	Body	Body Control Module			V																																			V	V																		
C	2008	Sierra	Body	Body Control Module (aux.)																																																									
C	2008	Sierra	Body	Digital Radio Receiver																																																									
C	2008	Sierra	Body	Driver Door Switch																																				V	V	V																		
C	2008	Sierra	Body	HVAC Control Module Auto																																						V		V																	
C	2008	Sierra	Body	HVAC Control Module Manual																																						V		V																	
C	2008	Sierra	Body	Instrument Panel Cluster																																																									
C	2008	Sierra	Body	Memory Seat Module																																																									
C	2008	Sierra	Body	Park Assist Module																																																									
C	2008	Sierra	Body	Passenger Door Switch																																				V	V	V																		
C	2008	Sierra	Body	Passenger Presence System																																				V																					
C	2008	Sierra	Body	Radio																																																									
C	2008	Sierra	Body	Rear Heated Seat Module																																																										
C	2008	Sierra	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2008	Sierra	Body	Rollover Sensor																																																								
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																					V																			
C	2008	Sierra	Body	Theft Deterrent Module																																																								
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																							
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																							
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																						
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																							
C	2008	Yukon	Chassis	Electronic Brake Control Module																																			V																					
C	2008	Yukon	Chassis	Electronic Suspension Control																																																								
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																								
C	2008	Yukon	Body	Amplifier (Bose)																																																								
C	2008	Yukon	Body	Assist Step Controller																																																								
C	2008	Yukon	Body	Body Control Module			V																																			V	V																	
C	2008	Yukon	Body	Body Control Module (aux.)																																																								
C	2008	Yukon	Body	Digital Radio Receiver																																																								
C	2008	Yukon	Body	Driver Door Switch																																					V	V	V																	
C	2008	Yukon	Body	HVAC Control Module Auto																																						V		V																
C	2008	Yukon	Body	HVAC Control Module Manual																																						V		V																
C	2008	Yukon	Body	Instrument Panel Cluster																																																								
C	2008	Yukon	Body	Lift Gate Module																																					V																			
C	2008	Yukon	Body	Memory Seat Module																																																								
C	2008	Yukon	Body	Park Assist Module																																																								
C	2008	Yukon	Body	Passenger Door Switch																																					V	V	V																	
C	2008	Yukon	Body	Passenger Presence System																																					V																			
C	2008	Yukon	Body	Radio																																																								
C	2008	Yukon	Body	Rear Heated Seat Module																																																								
C	2008	Yukon	Body	Rear HVAC/RSA																																																								
C	2008	Yukon	Body	Rollover Sensor																																																								
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																					V																			
C	2008	Yukon	Body	Theft Deterrent Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																								
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																									
C	2008	Yukon Hybrid	Body	Body Control Module			V																																			V	V																	
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																								
C	2008	Yukon Hybrid	Body	Driver Door Switch																																					V	V	V																		
C	2008	Yukon Hybrid	Body	HVAC Control Module																																						V		V																
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
C	2008	Yukon Hybrid	Body	Lift Gate Module																																					V																				
C	2008	Yukon Hybrid	Body	Memory Seat Module																																																									
C	2008	Yukon Hybrid	Body	Park Assist Module																																																									
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																					V	V	V																		
C	2008	Yukon Hybrid	Body	Passenger Presence System																																					V																				
C	2008	Yukon Hybrid	Body	Radio																																																									
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																									
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																					V																				
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																									
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																											
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																								
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																											
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																							
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																											
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																								
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																											
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																							
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																											
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																								
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																								
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																									
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																									
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																									
C	2008	Yukon XL	Body	Amplifier (Bose)																																																									
C	2008	Yukon XL	Body	Assist Step Controller																																																									
C	2008	Yukon XL	Body	Body Control Module			V																																			V	V																	
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																									
C	2008	Yukon XL	Body	Digital Radio Receiver																																																									
C	2008	Yukon XL	Body	Driver Door Switch																																					V	V	V																		
C	2008	Yukon XL	Body	HVAC Control Module Auto																																						V		V																
C	2008	Yukon XL	Body	HVAC Control Module Manual																																						V		V																
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																									
C	2008	Yukon XL	Body	Lift Gate Module																																					V																				
C	2008	Yukon XL	Body	Memory Seat Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2008	Yukon XL	Body	Park Assist Module																																																							
C	2008	Yukon XL	Body	Passenger Door Switch																																				V	V	V																	
C	2008	Yukon XL	Body	Passenger Presence System																																				V																			
C	2008	Yukon XL	Body	Radio																																																						
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																						
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																						
C	2008	Yukon XL	Body	Rollover Sensor																																																						
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																				V																			
C	2008	Yukon XL	Body	Theft Deterrent Module																																																						
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																										
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																						
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																	V	V																						
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																											
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																						
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																	V	V																						
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																										
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																											V		V	V																										
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																						
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																						
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																	V	V																						
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																						
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V											V																							
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																						
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																						
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																															
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																						
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																						
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual																											V		V	V																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																			V																			
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																						
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																						
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																						
C	2009	Sierra	Chassis	Electronic Suspension Control																																																						
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																						
C	2009	Sierra	Body	Amplifier (Bose)																																																						
C	2009	Sierra	Body	Body Control Module			V																																			V	V																
C	2009	Sierra	Body	Body Control Module (aux.)																																																						
C	2009	Sierra	Body	Digital Radio Receiver																																																						
C	2009	Sierra	Body	Driver Door Switch																																				V	V	V																	
C	2009	Sierra	Body	HVAC Control Module Auto																																						V		V															

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2009	Sierra	Body	HVAC Control Module Manual																																							V		V																
C	2009	Sierra	Body	Instrument Panel Cluster																																																								
C	2009	Sierra	Body	Memory Seat Module																																																								
C	2009	Sierra	Body	Park Assist Module																																																								
C	2009	Sierra	Body	Passenger Door Switch																																					V	V	V																		
C	2009	Sierra	Body	Passenger Presence System																																					V																			
C	2009	Sierra	Body	Radio																																																								
C	2009	Sierra	Body	Rear Heated Seat Module																																																								
C	2009	Sierra	Body	Rear HVAC/RSA																																																								
C	2009	Sierra	Body	Rollover Sensor																																																								
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																					V																			
C	2009	Sierra	Body	Theft Deterrent Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V		V																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																								
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																								
C	2009	Sierra Hybrid	Body	Body Control Module			V																																			V	V																		
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																								
C	2009	Sierra Hybrid	Body	Driver Door Switch																																					V	V	V																		
C	2009	Sierra Hybrid	Body	HVAC Control Module																																							V		V																
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
C	2009	Sierra Hybrid	Body	Memory Seat Module																																																								
C	2009	Sierra Hybrid	Body	Park Assist Module																																																								
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																					V	V	V																		
C	2009	Sierra Hybrid	Body	Passenger Presence System																																					V																			
C	2009	Sierra Hybrid	Body	Radio																																																								
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																								
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																					V																			
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed																											V		V	V																											
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed																											V		V	V																											
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																V	V																							
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																V	V	V		V	V	V										V																							
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																											
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V										V																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																											
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																								
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																											
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																								
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed																											V		V	V																											
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed																											V		V	V																											
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																	V	V																								
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																V	V	V		V	V	V											V																								
C	2009	Yukon	Chassis	Electronic Brake Control Module																																			V																						
C	2009	Yukon	Chassis	Electronic Suspension Control																																																									
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																									
C	2009	Yukon	Body	Amplifier (Bose)																																																									
C	2009	Yukon	Body	Assist Step Controller																																																									
C	2009	Yukon	Body	Body Control Module			V																																			V	V																		
C	2009	Yukon	Body	Body Control Module (aux.)																																																									
C	2009	Yukon	Body	Digital Radio Receiver																																																									
C	2009	Yukon	Body	Driver Door Switch																																					V	V	V																		
C	2009	Yukon	Body	HVAC Control Module Auto																																						V		V																	
C	2009	Yukon	Body	HVAC Control Module Manual																																						V		V																	
C	2009	Yukon	Body	Instrument Panel Cluster																																																									
C	2009	Yukon	Body	Left Side Object Detection Module																																																									
C	2009	Yukon	Body	Lift Gate Module																																					V																				
C	2009	Yukon	Body	Memory Seat Module																																																									
C	2009	Yukon	Body	Park Assist Module																																																									
C	2009	Yukon	Body	Passenger Door Switch																																					V	V	V																		
C	2009	Yukon	Body	Passenger Presence System																																					V																				
C	2009	Yukon	Body	Radio																																																									
C	2009	Yukon	Body	Rear Heated Seat Module																																																									
C	2009	Yukon	Body	Rear HVAC/RSA																																																									
C	2009	Yukon	Body	Right Side Object Detection Module																																																									
C	2009	Yukon	Body	Rollover Sensor																																																									
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																					V																				
C	2009	Yukon	Body	Theft Deterrent Module																																																									
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																									
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																									
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																									
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																									
C	2009	Yukon Hybrid	Body	Body Control Module			V																																			V	V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2009	Yukon Hybrid	Body	Driver Door Switch																																					V	V	V																			
C	2009	Yukon Hybrid	Body	Heated Seat Module																																																									
C	2009	Yukon Hybrid	Body	HVAC Control Module																																						V		V																		
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																									
C	2009	Yukon Hybrid	Body	Park Assist Module																																																									
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																					V	V	V																		
C	2009	Yukon Hybrid	Body	Passenger Presence System																																					V																		
C	2009	Yukon Hybrid	Body	Radio																																																									
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																									
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																					V																			
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																									
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																											
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																	V	V																						
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																											
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																						
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																											
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																	V	V																						
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																											
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																											
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																			V																					
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																									
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																									
C	2009	Yukon XL	Body	Amplifier (Bose)																																																									
C	2009	Yukon XL	Body	Assist Step Controller																																																									
C	2009	Yukon XL	Body	Body Control Module			V																																			V	V																		
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																									
C	2009	Yukon XL	Body	Digital Radio Receiver																																																									
C	2009	Yukon XL	Body	Driver Door Switch																																					V	V	V																		
C	2009	Yukon XL	Body	HVAC Control Module Auto																																						V		V																	
C	2009	Yukon XL	Body	HVAC Control Module Manual																																						V		V																	
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																									
C	2009	Yukon XL	Body	Left Side Object Detection Module																																																									
C	2009	Yukon XL	Body	Lift Gate Module																																					V																			
C	2009	Yukon XL	Body	Memory Seat Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2009	Yukon XL	Body	Park Assist Module																																																									
C	2009	Yukon XL	Body	Passenger Door Switch																																					V	V	V																		
C	2009	Yukon XL	Body	Passenger Presence System																																					V																				
C	2009	Yukon XL	Body	Radio																																																								
C	2009	Yukon XL	Body	Rear Heated Seat Module																																																									
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																									
C	2009	Yukon XL	Body	Right Side Object Detection Module																																																									
C	2009	Yukon XL	Body	Rollover Sensor																																																									
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																					V																				
C	2009	Yukon XL	Body	Theft Deterrent Module																																																									
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																												
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																											V		V	V																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																								
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																												
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																								
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																								
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																	
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																								
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																								
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																				V																				
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																									
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
C	2010	Sierra	Chassis	Electronic Suspension Control																																																									
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																									
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Sierra	Body	Amplifier (Bose)																																																									
C	2010	Sierra	Body	Body Control Module			V																																			V	V																		
C	2010	Sierra	Body	Body Control Module (aux.)																																																									
C	2010	Sierra	Body	Digital Radio Receiver																																																									
C	2010	Sierra	Body	Driver Door Switch																																					V	V	V																		
C	2010	Sierra	Body	HVAC Control Module Auto																																						V		V																	
C	2010	Sierra	Body	HVAC Control Module Manual																																						V		V																	
C	2010	Sierra	Body	Instrument Panel Cluster																																																									
C	2010	Sierra	Body	Memory Seat Module																																																									
C	2010	Sierra	Body	Park Assist Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2010	Sierra	Body	Passenger Door Switch																																					V	V	V																	
C	2010	Sierra	Body	Passenger Presence System																																					V																			
C	2010	Sierra	Body	Radio																																																								
C	2010	Sierra	Body	Rear Heated Seat Module																																																								
C	2010	Sierra	Body	Rear HVAC/RSA																																																								
C	2010	Sierra	Body	Supplemental Inflatable Restraint																																																								
C	2010	Sierra	Body	Theft Deterrent Module																																																								
C	2010	Sierra Hybrid	Powertrain	Engine Control Module																											V			V																												
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																								
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																								
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																								
C	2010	Sierra Hybrid	Body	Body Control Module			V																																			V	V																		
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																								
C	2010	Sierra Hybrid	Body	Driver Door Switch																																					V	V	V																		
C	2010	Sierra Hybrid	Body	Heated Seat Module																																																								
C	2010	Sierra Hybrid	Body	HVAC Control Module																																						V		V																	
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
C	2010	Sierra Hybrid	Body	Park Assist Module																																																								
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																					V	V	V																		
C	2010	Sierra Hybrid	Body	Passenger Presence System																																					V																			
C	2010	Sierra Hybrid	Body	Radio																																																								
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																								
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																											
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																V	V																							
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
C	2010	Yukon	Chassis	Electronic Brake Control Module																																			V																					
C	2010	Yukon	Chassis	Electronic Suspension Control																																																								
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Yukon	Body	Amplifier (Bose)																																																								
C	2010	Yukon	Body	Assist Step Controller																																																								
C	2010	Yukon	Body	Body Control Module			V																																			V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2010	Yukon	Body	Body Control Module (aux.)																																																									
C	2010	Yukon	Body	Digital Radio Receiver																																																										
C	2010	Yukon	Body	Driver Door Switch																																					V	V	V																			
C	2010	Yukon	Body	HVAC Control Module Auto																																						V		V																	
C	2010	Yukon	Body	HVAC Control Module Manual																																						V		V																	
C	2010	Yukon	Body	Instrument Panel Cluster																																																									
C	2010	Yukon	Body	Left Side Object Detection Module																																																									
C	2010	Yukon	Body	Lift Gate Module																																					V																					
C	2010	Yukon	Body	Memory Seat Module																																																									
C	2010	Yukon	Body	Park Assist Module																																																									
C	2010	Yukon	Body	Passenger Door Switch																																					V	V	V																			
C	2010	Yukon	Body	Passenger Presence System																																					V																					
C	2010	Yukon	Body	Radio																																																									
C	2010	Yukon	Body	Rear Heated Seat Module																																																										
C	2010	Yukon	Body	Rear HVAC/RSA																																																										
C	2010	Yukon	Body	Right Side Object Detection Module																																																										
C	2010	Yukon	Body	Supplemental Inflatable Restraint																																																										
C	2010	Yukon	Body	Theft Deterrent Module																																																										
C	2010	Yukon Hybrid	Powertrain	Engine Control Module																											V			V																													
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																										
C	2010	Yukon Hybrid	Body	Body Control Module			V																																			V	V																			
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2010	Yukon Hybrid	Body	Driver Door Switch																																					V	V	V																			
C	2010	Yukon Hybrid	Body	Heated Seat Module																																																										
C	2010	Yukon Hybrid	Body	HVAC Control Module																																						V		V																			
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
C	2010	Yukon Hybrid	Body	Lift Gate Module																																					V																					
C	2010	Yukon Hybrid	Body	Park Assist Module																																																										
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																					V	V	V																			
C	2010	Yukon Hybrid	Body	Passenger Presence System																																					V																					
C	2010	Yukon Hybrid	Body	Radio																																																										
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																								
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																										V		V	V																											
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																							
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																										V		V	V																											
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																							
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																V	V																							
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																										V		V	V																											
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																V	V																							
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																										V		V	V																											
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																							
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																V	V																							
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																										V		V	V																											
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																			V																					
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																							
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																							
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																							
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																							
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																							
C	2010	Yukon XL	Body	Amplifier (Bose)																																																							
C	2010	Yukon XL	Body	Assist Step Controller																																																							
C	2010	Yukon XL	Body	Body Control Module			V																																			V	V																	
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																							
C	2010	Yukon XL	Body	Digital Radio Receiver																																																							
C	2010	Yukon XL	Body	Driver Door Switch																																					V	V	V																	
C	2010	Yukon XL	Body	HVAC Control Module Auto																																						V		V																
C	2010	Yukon XL	Body	HVAC Control Module Manual																																						V		V																
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																							
C	2010	Yukon XL	Body	Left Side Object Detection Module																																																							
C	2010	Yukon XL	Body	Lift Gate Module																																					V																			
C	2010	Yukon XL	Body	Memory Seat Module																																																							
C	2010	Yukon XL	Body	Park Assist Module																																																							
C	2010	Yukon XL	Body	Passenger Door Switch																																					V	V	V																	
C	2010	Yukon XL	Body	Passenger Presence System																																					V																			
C	2010	Yukon XL	Body	Radio																																																							
C	2010	Yukon XL	Body	Rear Heated Seat Module																																																							
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																							
C	2010	Yukon XL	Body	Right Side Object Detection Module																																																							
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																							
C	2010	Yukon XL	Body	Theft Deterrent Module																																																							
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																										V		V	V																											
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																									V																															
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																							
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																V	V	V		V	V	V	V		V																															
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																									V																															
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																							
D	2008	ALL	Chassis	Electronic Brake Control Module																																																							
D	2008	ALL	Body	Body Control Module			V																																			V	V																	
D	2008	ALL	Body	Body Control Module (aux.)																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
D	2008	ALL	Body	Headlamp Control Module																																																								
D	2008	ALL	Body	HVAC Control Module Auto																																																								
D	2008	ALL	Body	Instrument Panel Cluster																																					V																			
D	2008	ALL	Body	Park Assist Module																																																								
D	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
D	2008	ALL	Body	Supplemental Inflatable Restraint																																					V																			
D	2008	ALL	Body	Theft Deterrent Module																																																								
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																											V		V	V																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																										V																														
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																								
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																V	V	V		V	V	V	V		V																															
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																										V																														
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																								
D	2009	ALL	Chassis	Electronic Brake Control Module																																																								
D	2009	ALL	Body	Body Control Module			V																																				V	V																
D	2009	ALL	Body	Body Control Module (aux.)																																																								
D	2009	ALL	Body	Headlamp Control Module																																																								
D	2009	ALL	Body	HVAC Control Module Auto																																																								
D	2009	ALL	Body	Instrument Panel Cluster																																					V																			
D	2009	ALL	Body	Park Assist Module																																																								
D	2009	ALL	Body	Remote Control Door Lock Receiver																																																								
D	2009	ALL	Body	Supplemental Inflatable Restraint																																					V																			
D	2009	ALL	Body	Theft Deterrent Module																																																								
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																											V		V	V																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																										V																														
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																								
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																											V		V	V																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																V	V																							
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																								
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																V	V	V		V	V	V	V		V																															
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																										V																														
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																								
D	2010	ALL	Chassis	Electronic Brake Control Module																																																								
D	2010	ALL	Body	Body Control Module			V																																				V	V																
D	2010	ALL	Body	Body Control Module (aux.)																																																								
D	2010	ALL	Body	Headlamp Control Module																																																								
D	2010	ALL	Body	HVAC Control Module Auto																																																								
D	2010	ALL	Body	Instrument Panel Cluster																																					V																			
D	2010	ALL	Body	Park Assist Module																																																								
D	2010	ALL	Body	Remote Control Door Lock Receiver																																																								
D	2010	ALL	Body	Supplemental Inflatable Restraint																																					V																			
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																		
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																		
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																		
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																	
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																	
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																							
G	2004	Express/Savana	Chassis	VSES																																																							
G	2004	Express/Savana	Body	Body Control Module																																					V	V	V																	
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																							
G	2004	Express/Savana	Body	OnStar																																																							
G	2004	Express/Savana	Body	Base Radio																																																							
G	2004	Express/Savana	Body	Uplevel Radio																																																							
G	2004	Express/Savana	Body	Remote Function Actuation																																																							
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																					V	V																		
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																		
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																		
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																		
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																		
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																							
G	2004	Express Access/Savana Pro	Chassis	VSES																																																							
G	2004	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																	
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																							
G	2004	Express Access/Savana Pro	Body	OnStar																																																							
G	2004	Express Access/Savana Pro	Body	Base Radio																																																							
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																							
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																							
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V	V																		
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control													V	V																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control													V	V																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module													V	V																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																V	V	V		V	V	V																																		
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																	
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																						
G	2005	Express/Savana	Chassis	VSES																																																						
G	2005	Express/Savana	Body	Body Control Module																																					V	V	V																
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																						
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																						
G	2005	Express/Savana	Body	Base Radio																																																						
G	2005	Express/Savana	Body	Uplevel Radio																																																						
G	2005	Express/Savana	Body	Remote Function Actuation																																																						
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		V
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																						
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																								
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control													V	V																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control													V	V																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module													V	V																																								
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																V	V	V		V	V	V																																
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																						
G	2005	Express Access/Savana Pro	Chassis	VSES																																																						
G	2005	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																						
G	2005	Express Access/Savana Pro	Body	Base Radio																																																						
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																						
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																						
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		V
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																						
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																								
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control													V	V																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control													V	V																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																	
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																V	V	V		V	V	V																																	
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																						
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																						
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																						
G	2006	Express/Savana	Chassis	VSES																																																						
G	2006	Express/Savana	Body	Body Control Module																																					V	V	V																	
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																						
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																						
G	2006	Express/Savana	Body	Passenger Presence System																																																						
G	2006	Express/Savana	Body	Base Radio																																																						
G	2006	Express/Savana	Body	Uplevel Radio																																																						
G	2006	Express/Savana	Body	Remote Function Actuation																																																						
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		V
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																						
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																									
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																	
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control													V	V																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																	
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control													V	V																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																	
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																	
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																	
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																	
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																	
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																V	V	V		V	V	V																																	
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																						
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																						
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																						
G	2006	Express Access/Savana Pro	Chassis	VSES																																																						
G	2006	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																	
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																						
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																						
G	2006	Express Access/Savana Pro	Body	Base Radio																																																						
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																						
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																						
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		V
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																						
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																									
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																	
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control													V	V																																									
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																	
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control													V	V																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																			
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																		
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																V	V	V		V	V	V																																		
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																							
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																							
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V	V	V	V																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																V	V	V		V	V	V																																		
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																							
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																							
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2007	Express/Savana	Body	Body Control Module																																					V	V	V																	
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																							
G	2007	Express/Savana	Body	Passenger Presence System																																																							
G	2007	Express/Savana	Body	Base Radio																																																							
G	2007	Express/Savana	Body	Uplevel Radio																																																							
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																			V
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																							
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control													V	V																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control													V	V																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																		
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control													V	V																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control													V	V																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																V	V	V		V	V	V																																		
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																							
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																							
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V	V	V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																V	V	V		V	V	V																																			
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																									
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2007	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																			
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2007	Express Access/Savana Pro	Body	Radio																																																									
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																			V
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																													
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V													V																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																												
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																			
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V													V																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																												
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																			
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																V	V	V		V	V	V																																			
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2008	Express/Savana	Body	Body Control Module			V																																			V	V																	
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2008	Express/Savana	Body	Passenger Presence System																																					V																				
G	2008	Express/Savana	Body	Radio																																																								
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2008	Express/Savana	Body	Rollover Sensor																																																									
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																				
G	2008	Express/Savana	Body	Theft Deterrent Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																													
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V													V																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																												
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V													V																								
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																												
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																												
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																V	V	V		V	V	V																																			
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2008	Express Access/Savana Pro	Body	Body Control Module			V																																				V	V																	
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																					V																					
G	2008	Express Access/Savana Pro	Body	Radio																																																									
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																					
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																													
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																												
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																			
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																												
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																								
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																												
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																			
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																												
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																V	V	V		V	V	V																																			
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2009	Express/Savana	Body	Body Control Module			V																																				V	V																	
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2009	Express/Savana	Body	Passenger Presence System																																					V																					
G	2009	Express/Savana	Body	Radio																																																									
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2009	Express/Savana	Body	Rollover Sensor																																																									
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																					
G	2009	Express/Savana	Body	Theft Deterrent Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																													
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																												
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																			
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																												
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																								
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																												
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																			
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																												
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																V	V	V		V	V	V																																			
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2009	Express Access/Savana Pro	Body	Body Control Module			V																																				V	V																	
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																					V																					
G	2009	Express Access/Savana Pro	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																			
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																						
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																							
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																	V	V																						
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																	V	V																						
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2010	Express/Savana	Body	Body Control Module			V																																			V	V																	
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2010	Express/Savana	Body	Passenger Presence System																																					V																			
G	2010	Express/Savana	Body	Radio																																																								
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2010	Express/Savana	Body	Rollover Sensor																																																								
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																			
G	2010	Express/Savana	Body	Theft Deterrent Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																						
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																							
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																	V	V																						
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																										
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																	V	V																						
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2010	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																					V																				
G	2010	Express Access/Savana Pro	Body	Radio																																																								
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																				
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																		
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2004	Express/Savana	Chassis	VSES																																																									
H	2004	Express/Savana	Body	Body Control Module																																					V	V	V																			
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2004	Express/Savana	Body	OnStar																																																								
H	2004	Express/Savana	Body	Base Radio																																																								
H	2004	Express/Savana	Body	Uplevel Radio																																																								
H	2004	Express/Savana	Body	Remote Function Actuation																																																								
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																					V	V																			
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																		
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
H	2004	Express Access/Savana Pro	Chassis	VSES																																																									
H	2004	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																			
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2004	Express Access/Savana Pro	Body	OnStar																																																									
H	2004	Express Access/Savana Pro	Body	Base Radio																																																									
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V	V																			
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2005	Express/Savana	Chassis	VSES																																																									
H	2005	Express/Savana	Body	Body Control Module																																					V	V	V																			
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2005	Express/Savana	Body	Base Radio																																																									
H	2005	Express/Savana	Body	Uplevel Radio																																																									
H	2005	Express/Savana	Body	Remote Function Actuation																																																									
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																				V
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																											
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																		
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																		
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2005	Express Access/Savana Pro	Chassis	VSES																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2005	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																	
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																							
H	2005	Express Access/Savana Pro	Body	Base Radio																																																							
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																							
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																							
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																			V
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																							
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																	
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																	
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																							
H	2006	Express/Savana	Chassis	VSES																																																							
H	2006	Express/Savana	Body	Body Control Module																																					V	V	V																	
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																							
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																							
H	2006	Express/Savana	Body	Passenger Presence System																																																							
H	2006	Express/Savana	Body	Base Radio																																																							
H	2006	Express/Savana	Body	Uplevel Radio																																																							
H	2006	Express/Savana	Body	Remote Function Actuation																																																							
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																			V
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																							
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																	
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																	
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																							
H	2006	Express Access/Savana Pro	Chassis	VSES																																																							
H	2006	Express Access/Savana Pro	Body	Body Control Module																																					V	V	V																	
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																							
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																							
H	2006	Express Access/Savana Pro	Body	Base Radio																																																							
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																							
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																							
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																			V
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																							
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																									
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																	
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																	
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																	
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
H	2007	Express/Savana	Body	Body Control Module																																					V	V	V																	
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																							
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																							
H	2007	Express/Savana	Body	Passenger Presence System																																																							
H	2007	Express/Savana	Body	Base Radio																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2007	Express/Savana	Body	Uplevel Radio																																																							
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																						V																	V
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																							
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																									
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																	
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control													V	V																																									
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																V	V	V		V	V	V																																	
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control													V	V																																									
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																V	V	V		V	V	V																																	
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																							
H	2007	Express Access/Savana Pro	Body	Body Control Module																																						V	V	V																
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																							
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																							
H	2007	Express Access/Savana Pro	Body	Base Radio																																																							
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																							
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																						V																	V
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																							
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V												V																							
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																									
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																	
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																									
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V												V																							
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																									
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																	
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
H	2008	Express/Savana	Body	Body Control Module		V																																					V	V															
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																							
H	2008	Express/Savana	Body	Passenger Presence System																																						V																	
H	2008	Express/Savana	Body	Radio																																																							
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
H	2008	Express/Savana	Body	Rollover Sensor																																																							
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																						V																	
H	2008	Express/Savana	Body	Theft Deterrent Module																																																							
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V												V																							
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																									
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																	
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																									
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V												V																							
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																									
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																	
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2008	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V																
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																					V																			
H	2008	Express Access/Savana Pro	Body	Radio																																																						
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																						
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																			
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																						
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																											
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V										V																							
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																	
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																							
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																	
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																						
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																						
H	2009	Express/Savana	Body	Body Control Module			V																																			V	V																
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																						
H	2009	Express/Savana	Body	Passenger Presence System																																					V																			
H	2009	Express/Savana	Body	Radio																																																						
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
H	2009	Express/Savana	Body	Rollover Sensor																																																						
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																			
H	2009	Express/Savana	Body	Theft Deterrent Module																																																						
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																											
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V										V																							
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V																																	
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																							
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																	
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																					
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																					
H	2009	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V																
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																					V																			
H	2009	Express Access/Savana Pro	Body	Radio																																																						
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																						
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																			
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																						
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																						
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																						
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																						
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																						
H	2010	Express/Savana	Body	Body Control Module			V																																			V	V																
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																						
H	2010	Express/Savana	Body	Passenger Presence System																																					V																		
H	2010	Express/Savana	Body	Radio																																																						
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
H	2010	Express/Savana	Body	Rollover Sensor																																																						
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		
H	2010	Express/Savana	Body	Theft Deterrent Module																																																						
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																						
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																						
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																						
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																						
H	2010	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V																
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																					V																		
H	2010	Express Access/Savana Pro	Body	Radio																																																						
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																						
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																						
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM													V	V																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																						
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																						
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																						
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																V	V	V		V	V	V																																
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																						
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																						
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																						
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																						
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																						
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																						
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																			
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module													V	V																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																V	V	V		V	V	V																																			
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																V	V	V		V	V	V																																			
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																											
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																			
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module													V	V																																											
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																				V	V	V	V	V																																	
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																											
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																				V	V	V	V	V																																	
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module													V	V																																											
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																V	V	V		V	V	V																																			
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																				V	V	V	V	V																																	
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																									
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
K	2004	ALL	Chassis	ESC																																																								
K	2004	ALL	Chassis	Rear Wheel Steering																																																									
K	2004	ALL	Chassis	Tire Pressure Monitor																																																									
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																									
K	2004	ALL	Chassis	VSES																																																								
K	2004	ALL	Body	Amplifier (Bose)																																																									
K	2004	ALL	Body	Body Control Module																																					V	V	V																		
K	2004	ALL	Body	CD Changer																																																									
K	2004	ALL	Body	Chime																																																									
K	2004	ALL	Body	Driver Door Module																																					V	V	V																		
K	2004	ALL	Body	Driver Seat Module																																																									
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2004	ALL	Body	Instrument Panel Cluster																																																										
K	2004	ALL	Body	OnStar																																																									
K	2004	ALL	Body	Passenger Door Module																																					V	V	V																		
K	2004	ALL	Body	Passenger Presence System																																																									
K	2004	ALL	Body	Radio Base																																																									
K	2004	ALL	Body	Radio Uplevel																																																									
K	2004	ALL	Body	Radio Navigation																																																									
K	2004	ALL	Body	Rear Aux. Climate Module																																					V																				
K	2004	ALL	Body	Rear HVAC																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2004	ALL	Body	Rear Seat Audio																																						V																		
K	2004	ALL	Body	Rear Seat Entertainment																																																							
K	2004	ALL	Body	Supplemental Inflatable Restraint																																						V	V																		
K	2004	ALL	Body	Vehicle Theft Deterrent																																						V																		
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM													V	V																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																							
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																						
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																V	V	V		V	V	V																																	
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																						
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																	
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																	
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																						
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																						
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																	
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																						
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																	
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																						
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module													V	V																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																V	V	V		V	V	V																																	
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																						
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																	
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																						
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																						
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																	
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																						
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																						
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																						
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module													V	V																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																V	V	V		V	V	V																																	
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																V	V	V		V	V	V																																	
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																						
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																						
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																						
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																	
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																				V	V	V	V	V																															
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																						
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module													V	V																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																V	V	V		V	V	V																																	
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																				V	V	V	V	V																															
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																						
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																						
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																									
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
K	2005	ALL	Chassis	ESC																																																									
K	2005	ALL	Chassis	Rear Wheel Steering																																																									
K	2005	ALL	Chassis	Tire Pressure Monitor																																																									
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																									
K	2005	ALL	Chassis	VSES																																																									
K	2005	ALL	Body	Amplifier (Bose)																																																									
K	2005	ALL	Body	Body Control Module																																					V	V	V																			
K	2005	ALL	Body	CD Changer																																																									
K	2005	ALL	Body	Chime																																																									
K	2005	ALL	Body	Disc Player and Video Display																																																									
K	2005	ALL	Body	Driver Door Module																																					V	V	V																			
K	2005	ALL	Body	Driver Seat Module																																																									
K	2005	ALL	Body	Generator Battery Control Module																																																									
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																									
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2005	ALL	Body	Instrument Panel Cluster																																																									
K	2005	ALL	Body	Passenger Door Module																																					V	V	V																			
K	2005	ALL	Body	Passenger Presence System																																																									
K	2005	ALL	Body	Base Radio																																																									
K	2005	ALL	Body	Uplevel Radio																																																									
K	2005	ALL	Body	Navigation Radio																																																									
K	2005	ALL	Body	Rear Aux. Climate Module																																					V																					
K	2005	ALL	Body	Rear HVAC																																																									
K	2005	ALL	Body	Rear Seat Audio																																					V																					
K	2005	ALL	Body	Supplemental Inflatable Restraint																																					V																					V
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2005	ALL	Body	Vehicle Theft Deterrent																																					V																					
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM													V	V																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM													V	V																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM													V	V																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																V	V	V		V	V	V																																			
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module													V	V																																											
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																V	V	V		V	V	V																																			

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module													V	V																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																V	V	V		V	V	V																																				
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module													V	V																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																V	V	V		V	V	V																																				
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module													V	V																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																V	V	V		V	V	V																																				
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																V	V	V		V	V	V																																				
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module													V	V																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																V	V	V		V	V	V																																				
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module													V	V																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																				V	V	V	V	V																																		
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module													V	V																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																				V	V	V	V	V																																		
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module													V	V																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																				V	V	V	V	V																																		
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																V	V	V		V	V	V																																				
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2006	ALL	Chassis	ESC																																																									
K	2006	ALL	Chassis	Tire Pressure Monitor																																																										
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2006	ALL	Chassis	VSES																																																									
K	2006	ALL	Body	Amplifier (Bose)																																																										
K	2006	ALL	Body	Body Control Module																																					V	V	V																			
K	2006	ALL	Body	CD Changer																																																										
K	2006	ALL	Body	Chime																																																										
K	2006	ALL	Body	Disc Player and Video Display																																																										
K	2006	ALL	Body	Driver Door Module																																					V	V	V																			
K	2006	ALL	Body	Driver Seat Module																																																										
K	2006	ALL	Body	Generator Battery Control Module																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																							
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																							
K	2006	ALL	Body	Instrument Panel Cluster																																																						
K	2006	ALL	Body	Passenger Door Module																																					V	V	V																
K	2006	ALL	Body	Passenger Presence System																																																						
K	2006	ALL	Body	Base Radio																																																						
K	2006	ALL	Body	Uplevel Radio																																																						
K	2006	ALL	Body	Navigation Radio																																																						
K	2006	ALL	Body	Rear Aux. Climate Module																																					V																		
K	2006	ALL	Body	Rear HVAC																																																						
K	2006	ALL	Body	Rear Seat Audio																																					V																		
K	2006	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
K	2006	ALL	Body	Vehicle Theft Deterrent																																					V																		
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																						
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																									
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V													V																						
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																						
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																									
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																						
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																						
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																						
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																						
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																						
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																						
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																						
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																									
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																					
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																						
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																									
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																						
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																						
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																						
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																									
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																						
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																						
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																						
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																									
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																						
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																					
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																									
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																															
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																						
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																						
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																						
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																									
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																						
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																						
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																									
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																						
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Sierra	Chassis	Electronic Suspension Control																																																									
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																									
K	2007	Sierra	Body	Amplifier (Bose)																																																									
K	2007	Sierra	Body	Body Control Module			V																																			V	V																	
K	2007	Sierra	Body	Body Control Module (aux.)																																																									
K	2007	Sierra	Body	Digital Radio Receiver																																																									
K	2007	Sierra	Body	Driver Door Switch																																					V	V	V																		
K	2007	Sierra	Body	HVAC Control Module Auto																																						V		V																	
K	2007	Sierra	Body	HVAC Control Module Manual																																						V		V																	
K	2007	Sierra	Body	Instrument Panel Cluster																																																									
K	2007	Sierra	Body	Memory Seat Module																																																									
K	2007	Sierra	Body	Park Assist Module																																																									
K	2007	Sierra	Body	Passenger Door Switch																																					V	V	V																		
K	2007	Sierra	Body	Passenger Presence System																																					V																				
K	2007	Sierra	Body	Radio																																																									
K	2007	Sierra	Body	Rear Heated Seat Module																																																									
K	2007	Sierra	Body	Rear HVAC/RSA																																																									
K	2007	Sierra	Body	Rollover Sensor																																																									
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																					V																				
K	2007	Sierra	Body	Theft Deterrent Module																																																									
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																											
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module															V	V	V		V														V																								
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																											
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module															V	V	V		V														V																								
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																									
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																											
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																							
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module															V	V	V		V														V																								
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Yukon	Chassis	Electronic Suspension Control																																																									
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																									
K	2007	Yukon	Body	Amplifier (Bose)																																																									
K	2007	Yukon	Body	Assist Step Controller																																																									
K	2007	Yukon	Body	Body Control Module			V																																			V	V																	
K	2007	Yukon	Body	Body Control Module (aux.)																																																									
K	2007	Yukon	Body	Digital Radio Receiver																																																									
K	2007	Yukon	Body	Driver Door Switch																																					V	V	V																		
K	2007	Yukon	Body	HVAC Control Module Auto																																						V		V																	
K	2007	Yukon	Body	HVAC Control Module Manual																																						V		V																	
K	2007	Yukon	Body	Instrument Panel Cluster																																																									
K	2007	Yukon	Body	Lift Gate Module																																					V																				
K	2007	Yukon	Body	Memory Seat Module																																																									
K	2007	Yukon	Body	Park Assist Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2007	Yukon	Body	Passenger Door Switch																																					V	V	V																
K	2007	Yukon	Body	Passenger Presence System																																					V																		
K	2007	Yukon	Body	Radio																																																							
K	2007	Yukon	Body	Rear Heated Seat Module																																																							
K	2007	Yukon	Body	Rear HVAC/RSA																																																							
K	2007	Yukon	Body	Rollover Sensor																																																							
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																					V																		
K	2007	Yukon	Body	Theft Deterrent Module																																																							
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																										
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																							
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																							
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																										
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																V	V	V		V	V	V																																		
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																							
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																							
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																							
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																										
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																						
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																							
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																							
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																							
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																							
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																							
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																							
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																							
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																							
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																							
K	2007	Yukon XL	Body	Amplifier (Bose)																																																							
K	2007	Yukon XL	Body	Assist Step Controller																																																							
K	2007	Yukon XL	Body	Body Control Module			V																																			V	V																	
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																							
K	2007	Yukon XL	Body	Digital Radio Receiver																																																							
K	2007	Yukon XL	Body	Driver Door Switch																																					V	V	V																	
K	2007	Yukon XL	Body	HVAC Control Module Auto																																						V		V																
K	2007	Yukon XL	Body	HVAC Control Module Manual																																						V		V																
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																							
K	2007	Yukon XL	Body	Lift Gate Module																																					V																		
K	2007	Yukon XL	Body	Memory Seat Module																																																							
K	2007	Yukon XL	Body	Park Assist Module																																																							
K	2007	Yukon XL	Body	Passenger Door Switch																																					V	V	V																	
K	2007	Yukon XL	Body	Passenger Presence System																																					V																		
K	2007	Yukon XL	Body	Radio																																																							
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																							
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																							
K	2007	Yukon XL	Body	Rollover Sensor																																																							
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																					V																		
K	2007	Yukon XL	Body	Theft Deterrent Module																																																							
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																								
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																												
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V													V																								
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																											
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																								
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																											
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																							
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																											
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																								
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																											
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																								
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																											
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																							
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																											
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																	
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																											
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																								
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																								
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																			V																					
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2008	Sierra	Chassis	Electronic Suspension Control																																																								
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																								
K	2008	Sierra	Body	Amplifier (Bose)																																																								
K	2008	Sierra	Body	Body Control Module			V																																			V	V																	
K	2008	Sierra	Body	Body Control Module (aux.)																																																									
K	2008	Sierra	Body	Digital Radio Receiver																																																									
K	2008	Sierra	Body	Driver Door Switch																																					V	V	V																	
K	2008	Sierra	Body	HVAC Control Module Auto																																						V		V																
K	2008	Sierra	Body	HVAC Control Module Manual																																						V		V																
K	2008	Sierra	Body	Instrument Panel Cluster																																																								
K	2008	Sierra	Body	Memory Seat Module																																																								
K	2008	Sierra	Body	Park Assist Module																																																								
K	2008	Sierra	Body	Passenger Door Switch																																					V	V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2008	Sierra	Body	Passenger Presence System																																					V																		
K	2008	Sierra	Body	Radio																																																						
K	2008	Sierra	Body	Rear Heated Seat Module																																																						
K	2008	Sierra	Body	Rear HVAC/RSA																																																						
K	2008	Sierra	Body	Rollover Sensor																																																						
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																					V																		
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																						
K	2008	Sierra	Body	Theft Deterrent Module																																																						
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																									
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																						
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																						
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																						
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																									
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																						
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V													V																						
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																									
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																						
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																					
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																									
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																						
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																						
K	2008	Yukon	Chassis	Electronic Brake Control Module																																			V																			
K	2008	Yukon	Chassis	Electronic Suspension Control																																																						
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																						
K	2008	Yukon	Body	Amplifier (Bose)																																																						
K	2008	Yukon	Body	Assist Step Controller																																																						
K	2008	Yukon	Body	Body Control Module			V																																			V	V																
K	2008	Yukon	Body	Body Control Module (aux.)																																																						
K	2008	Yukon	Body	Digital Radio Receiver																																																						
K	2008	Yukon	Body	Driver Door Switch																																					V	V	V																
K	2008	Yukon	Body	HVAC Control Module Auto																																						V		V															
K	2008	Yukon	Body	HVAC Control Module Manual																																						V		V															
K	2008	Yukon	Body	Instrument Panel Cluster																																																						
K	2008	Yukon	Body	Lift Gate Module																																					V																		
K	2008	Yukon	Body	Memory Seat Module																																																						
K	2008	Yukon	Body	Park Assist Module																																																						
K	2008	Yukon	Body	Passenger Door Switch																																					V	V	V																
K	2008	Yukon	Body	Passenger Presence System																																					V																		
K	2008	Yukon	Body	Radio																																																						
K	2008	Yukon	Body	Rear Heated Seat Module																																																						
K	2008	Yukon	Body	Rear HVAC/RSA																																																						
K	2008	Yukon	Body	Rollover Sensor																																																						
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																					V																		
K	2008	Yukon	Body	Theft Deterrent Module																																																						
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																									
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																						
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																						
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																						
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																						
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																							
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																							
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																							
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																							
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																							
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																							
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																							
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																							
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																							
K	2008	Yukon Hybrid	Body	Body Control Module			V																																			V	V																
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																							
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																							
K	2008	Yukon Hybrid	Body	Driver Door Switch																																					V	V	V																	
K	2008	Yukon Hybrid	Body	HVAC Control Module																																						V		V																
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																							
K	2008	Yukon Hybrid	Body	Lift Gate Module																																					V																			
K	2008	Yukon Hybrid	Body	Memory Seat Module																																																							
K	2008	Yukon Hybrid	Body	Park Assist Module																																																							
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																					V	V	V																	
K	2008	Yukon Hybrid	Body	Passenger Presence System																																					V																			
K	2008	Yukon Hybrid	Body	Radio																																																							
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																							
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																							
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																							
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																							
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																					V																			
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																							
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																										
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																							
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																V	V	V		V													V																							
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																							
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																											V		V	V																										
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																						
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																							
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																										
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																							
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																V	V	V		V													V																							
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																							
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																											V		V	V																										
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																							
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																	V	V																						
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																							
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																V	V	V		V													V																							
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																							
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																V	V	V		V													V																							
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																							
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																							
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																									
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2008	Yukon XL	Body	Amplifier (Bose)																																																										
K	2008	Yukon XL	Body	Assist Step Controller																																																										
K	2008	Yukon XL	Body	Body Control Module			V																																			V	V																		
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2008	Yukon XL	Body	Digital Radio Receiver																																																										
K	2008	Yukon XL	Body	Driver Door Switch																																					V	V	V																			
K	2008	Yukon XL	Body	HVAC Control Module Auto																																						V		V																	
K	2008	Yukon XL	Body	HVAC Control Module Manual																																						V		V																	
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2008	Yukon XL	Body	Lift Gate Module																																					V																					
K	2008	Yukon XL	Body	Memory Seat Module																																																										
K	2008	Yukon XL	Body	Park Assist Module																																																										
K	2008	Yukon XL	Body	Passenger Door Switch																																					V	V	V																			
K	2008	Yukon XL	Body	Passenger Presence System																																					V																					
K	2008	Yukon XL	Body	Radio																																																										
K	2008	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2008	Yukon XL	Body	Rollover Sensor																																																										
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																					V																					
K	2008	Yukon XL	Body	Theft Deterrent Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																												
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																	V	V																								
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V																													
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																												
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																	V	V																								
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																											V		V	V																												
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul																											V		V	V																												
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																								
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																												
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																	V	V																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																V	V	V		V	V	V											V																								
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																												
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V											V																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																												
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																											
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																											
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																	V	V																						
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																V	V	V		V	V	V											V																						
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																			V																				
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																							
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																							
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																							
K	2009	Sierra	Chassis	Electronic Suspension Control																																																							
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																							
K	2009	Sierra	Body	Amplifier (Bose)																																																							
K	2009	Sierra	Body	Body Control Module			V																																			V	V																
K	2009	Sierra	Body	Body Control Module (aux.)																																																							
K	2009	Sierra	Body	Digital Radio Receiver																																																							
K	2009	Sierra	Body	Driver Door Switch																																					V	V	V																
K	2009	Sierra	Body	HVAC Control Module Auto																																						V		V															
K	2009	Sierra	Body	HVAC Control Module Manual																																						V		V															
K	2009	Sierra	Body	Instrument Panel Cluster																																																							
K	2009	Sierra	Body	Memory Seat Module																																																							
K	2009	Sierra	Body	Park Assist Module																																																							
K	2009	Sierra	Body	Passenger Door Switch																																					V	V	V																
K	2009	Sierra	Body	Passenger Presence System																																					V																		
K	2009	Sierra	Body	Radio																																																							
K	2009	Sierra	Body	Rear Heated Seat Module																																																							
K	2009	Sierra	Body	Rear HVAC/RSA																																																							
K	2009	Sierra	Body	Rollover Sensor																																																							
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																					V																		
K	2009	Sierra	Body	Theft Deterrent Module																																																							
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																							
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																							
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																							
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																							
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																							
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																							
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																							
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																							
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																							
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																							
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																							
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																							
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																								
K	2009	Sierra Hybrid	Body	Body Control Module			V																																			V	V																	
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																								
K	2009	Sierra Hybrid	Body	Driver Door Switch																																					V	V	V																		
K	2009	Sierra Hybrid	Body	HVAC Control Module																																						V		V																	
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
K	2009	Sierra Hybrid	Body	Memory Seat Module																																																									
K	2009	Sierra Hybrid	Body	Park Assist Module																																																									
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																					V	V	V																		
K	2009	Sierra Hybrid	Body	Passenger Presence System																																					V																				
K	2009	Sierra Hybrid	Body	Radio																																																									
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																									
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																									
K	2009	Sierra Hybrid	Body	Rollover Sensor																																																									
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																									
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																					V																				
K	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																									
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																											V		V	V																											
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																	V	V																							
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																											V		V	V																											
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																V	V	V		V	V	V											V																							
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																									
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																											
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																							
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																											
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																							
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																									
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																	V	V																							
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																V	V	V		V	V	V											V																							
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2009	Yukon	Chassis	Electronic Brake Control Module																																			V																						
K	2009	Yukon	Chassis	Electronic Suspension Control																																																									
K	2009	Yukon	Chassis	Trailer Brake Control Module																																																									
K	2009	Yukon	Body	Amplifier (Bose)																																																									
K	2009	Yukon	Body	Assist Step Controller																																																									
K	2009	Yukon	Body	Body Control Module			V																																			V	V																	
K	2009	Yukon	Body	Body Control Module (aux.)																																																									
K	2009	Yukon	Body	Digital Radio Receiver																																																									
K	2009	Yukon	Body	Driver Door Switch																																					V	V	V																		
K	2009	Yukon	Body	HVAC Control Module Auto																																						V		V																	
K	2009	Yukon	Body	HVAC Control Module Manual																																						V		V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2009	Yukon	Body	Instrument Panel Cluster																																																								
K	2009	Yukon	Body	Left Side Object Detection Module																																																								
K	2009	Yukon	Body	Lift Gate Module																																					V																			
K	2009	Yukon	Body	Memory Seat Module																																																							
K	2009	Yukon	Body	Park Assist Module																																																							
K	2009	Yukon	Body	Passenger Door Switch																																					V	V	V																	
K	2009	Yukon	Body	Passenger Presence System																																					V																			
K	2009	Yukon	Body	Radio																																																							
K	2009	Yukon	Body	Rear Heated Seat Module																																																							
K	2009	Yukon	Body	Rear HVAC/RSA																																																							
K	2009	Yukon	Body	Right Side Object Detection Module																																																							
K	2009	Yukon	Body	Rollover Sensor																																																							
K	2009	Yukon	Body	Supplemental Inflatable Restraint																																					V																			
K	2009	Yukon	Body	Theft Deterrent Module																																																							
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																											V			V																											
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																							
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																							
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																							
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																							
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																							
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																							
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																							
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																							
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																							
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																							
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																							
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																							
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																							
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																							
K	2009	Yukon Hybrid	Body	Body Control Module			V																																			V	V																
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																							
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																							
K	2009	Yukon Hybrid	Body	Driver Door Switch																																					V	V	V																	
K	2009	Yukon Hybrid	Body	Heated Seat Module																																																							
K	2009	Yukon Hybrid	Body	HVAC Control Module																																							V		V															
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																							
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																							
K	2009	Yukon Hybrid	Body	Park Assist Module																																																							
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																					V	V	V																	
K	2009	Yukon Hybrid	Body	Passenger Presence System																																					V																			
K	2009	Yukon Hybrid	Body	Radio																																																							
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																							
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																							
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																							
K	2009	Yukon Hybrid	Body	Rollover Sensor																																																							
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																							
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																					V																			
K	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																							
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																											V		V	V																											
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																							
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																V	V																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																							
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																										V		V	V																										
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																V	V																						
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																						
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																										V		V	V																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																						
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																V	V																						
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																						
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																										V		V	V																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																						
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																V	V																						
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																						
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																										V		V	V																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																						
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																V	V																						
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																						
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																										V		V	V																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																						
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																						
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																			V																				
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																					
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																					
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																					
K	2009	Yukon XL	Body	Amplifier (Bose)																																																					
K	2009	Yukon XL	Body	Assist Step Controller																																																					
K	2009	Yukon XL	Body	Body Control Module			V																																			V	V															
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																					
K	2009	Yukon XL	Body	Digital Radio Receiver																																																					
K	2009	Yukon XL	Body	Driver Door Switch																																					V	V	V															
K	2009	Yukon XL	Body	HVAC Control Module Auto																																						V		V														
K	2009	Yukon XL	Body	HVAC Control Module Manual																																						V		V														
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																					
K	2009	Yukon XL	Body	Left Side Object Detection Module																																																					
K	2009	Yukon XL	Body	Lift Gate Module																																					V																	
K	2009	Yukon XL	Body	Memory Seat Module																																																					
K	2009	Yukon XL	Body	Park Assist Module																																																					
K	2009	Yukon XL	Body	Passenger Door Switch																																					V	V	V															
K	2009	Yukon XL	Body	Passenger Presence System																																					V																	
K	2009	Yukon XL	Body	Radio																																																					
K	2009	Yukon XL	Body	Rear Heated Seat Module																																																					
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																					
K	2009	Yukon XL	Body	Right Side Object Detection Module																																																					
K	2009	Yukon XL	Body	Rollover Sensor																																																					
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																					V																	
K	2009	Yukon XL	Body	Theft Deterrent Module																																																					
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																										V		V	V																										
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V										V																							
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																						
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																										V		V	V																										
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																										V		V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																	V	V																						
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																							
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																											V			V																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																				V	V	V	V	V																																
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																			V																					
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																								
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
K	2010	Sierra	Chassis	Electronic Suspension Control																																																								
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																								
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Sierra	Body	Amplifier (Bose)																																																								
K	2010	Sierra	Body	Body Control Module			V																																			V	V																	
K	2010	Sierra	Body	Body Control Module (aux.)																																																								
K	2010	Sierra	Body	Digital Radio Receiver																																																								
K	2010	Sierra	Body	Driver Door Switch																																					V	V	V																	
K	2010	Sierra	Body	HVAC Control Module Auto																																						V		V																
K	2010	Sierra	Body	HVAC Control Module Manual																																						V		V																
K	2010	Sierra	Body	Instrument Panel Cluster																																																								
K	2010	Sierra	Body	Memory Seat Module																																																								
K	2010	Sierra	Body	Park Assist Module																																																								
K	2010	Sierra	Body	Passenger Door Switch																																					V	V	V																	
K	2010	Sierra	Body	Passenger Presence System																																					V																			
K	2010	Sierra	Body	Radio																																																								
K	2010	Sierra	Body	Rear Heated Seat Module																																																								
K	2010	Sierra	Body	Rear HVAC/RSA																																																								
K	2010	Sierra	Body	Supplemental Inflatable Restraint																																																								
K	2010	Sierra	Body	Theft Deterrent Module																																																								
K	2010	Sierra Hybrid	Powertrain	Engine Control Module																											V			V																											
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																									
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Sierra Hybrid	Body	Body Control Module			V																																			V	V																			
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Sierra Hybrid	Body	Driver Door Switch																																					V	V	V																			
K	2010	Sierra Hybrid	Body	Heated Seat Module																																																										
K	2010	Sierra Hybrid	Body	HVAC Control Module																																							V		V																		
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Sierra Hybrid	Body	Park Assist Module																																																										
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																					V	V	V																			
K	2010	Sierra Hybrid	Body	Passenger Presence System																																					V																					
K	2010	Sierra Hybrid	Body	Radio																																																										
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																												
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																V	V																									
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																									
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon	Chassis	Electronic Brake Control Module																																			V																						
K	2010	Yukon	Chassis	Electronic Suspension Control																																																										
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon	Body	Amplifier (Bose)																																																										
K	2010	Yukon	Body	Assist Step Controller																																																										
K	2010	Yukon	Body	Body Control Module			V																																			V	V																		
K	2010	Yukon	Body	Body Control Module (aux.)																																																										
K	2010	Yukon	Body	Digital Radio Receiver																																																										
K	2010	Yukon	Body	Driver Door Switch																																					V	V	V																		
K	2010	Yukon	Body	HVAC Control Module Auto																																							V		V																
K	2010	Yukon	Body	HVAC Control Module Manual																																							V		V																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2010	Yukon	Body	Instrument Panel Cluster																																																									
K	2010	Yukon	Body	Left Side Object Detection Module																																																										
K	2010	Yukon	Body	Lift Gate Module																																					V																					
K	2010	Yukon	Body	Memory Seat Module																																																									
K	2010	Yukon	Body	Park Assist Module																																																									
K	2010	Yukon	Body	Passenger Door Switch																																					V	V	V																		
K	2010	Yukon	Body	Passenger Presence System																																					V																				
K	2010	Yukon	Body	Radio																																																									
K	2010	Yukon	Body	Rear Heated Seat Module																																																										
K	2010	Yukon	Body	Rear HVAC/RSA																																																										
K	2010	Yukon	Body	Right Side Object Detection Module																																																										
K	2010	Yukon	Body	Supplemental Inflatable Restraint																																																										
K	2010	Yukon	Body	Theft Deterrent Module																																																										
K	2010	Yukon Hybrid	Powertrain	Engine Control Module																											V			V																												
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Yukon Hybrid	Body	Body Control Module			V																																			V	V																		
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Yukon Hybrid	Body	Driver Door Switch																																					V	V	V																		
K	2010	Yukon Hybrid	Body	Heated Seat Module																																																										
K	2010	Yukon Hybrid	Body	HVAC Control Module																																						V		V																		
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
K	2010	Yukon Hybrid	Body	Lift Gate Module																																					V																					
K	2010	Yukon Hybrid	Body	Park Assist Module																																																										
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																					V	V	V																		
K	2010	Yukon Hybrid	Body	Passenger Presence System																																					V																				
K	2010	Yukon Hybrid	Body	Radio																																																										
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																												
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																							
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																										
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																	V	V																						
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																			V																					
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																								
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																								
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																								
K	2010	Yukon XL	Body	Amplifier (Bose)																																																								
K	2010	Yukon XL	Body	Assist Step Controller																																																								
K	2010	Yukon XL	Body	Body Control Module			V																																			V	V																	
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																								
K	2010	Yukon XL	Body	Digital Radio Receiver																																																								
K	2010	Yukon XL	Body	Driver Door Switch																																					V	V	V																	
K	2010	Yukon XL	Body	HVAC Control Module Auto																																						V		V																
K	2010	Yukon XL	Body	HVAC Control Module Manual																																						V		V																
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																								
K	2010	Yukon XL	Body	Left Side Object Detection Module																																																								
K	2010	Yukon XL	Body	Lift Gate Module																																					V																			
K	2010	Yukon XL	Body	Memory Seat Module																																																								
K	2010	Yukon XL	Body	Park Assist Module																																																								
K	2010	Yukon XL	Body	Passenger Door Switch																																					V	V	V																	
K	2010	Yukon XL	Body	Passenger Presence System																																					V																			
K	2010	Yukon XL	Body	Radio																																																								
K	2010	Yukon XL	Body	Rear Heated Seat Module																																																								
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																								
K	2010	Yukon XL	Body	Right Side Object Detection Module																																																								
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
K	2010	Yukon XL	Body	Theft Deterrent Module																																																								
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
L	2004	ALL	Chassis	4WAL 3 Sensor																																																								
L	2004	ALL	Body	Body Control Module																																					V		V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2004	ALL	Body	Instrument Panel Cluster																																					V	V	V																	
L	2004	ALL	Body	Supplemental Inflatable Restraint																																					V	V																		
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																			
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
L	2005	ALL	Chassis	4WAL 3 Sensor																																																									
L	2005	ALL	Body	Body Control Module																																					V		V																		
L	2005	ALL	Body	Instrument Panel Cluster																																					V	V	V																		
L	2005	ALL	Body	Supplemental Inflatable Restraint																																					V	V																		
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																								
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																								
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																								
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																								
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																								
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																								
L	2010	Terrain	Chassis	Electronic Brake Control Module																																																								
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2010	Terrain	Body	Body Control Module																																																								
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2010	Terrain	Body	Passenger Presence Module																																																								
L	2010	Terrain	Body	Instrument Cluster																																																								
L	2010	Terrain	Body	Radio																																																								
L	2010	Terrain	Body	Multimedia Player Interface Module																																																								
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																																								
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																																								
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																																								
L	2010	Terrain	Body	Liftgate Control Module																																																								
L	2010	Terrain	Body	Parking Assist Control Module																																																								
L	2010	Terrain	Body	Frontview Camera Module																																																								
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																																								
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																																								
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																								
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																								
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																								
L	2011	Terrain	Chassis	Electronic Brake Control Module																																																								
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2011	Terrain	Body	Body Control Module																																																								
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2011	Terrain	Body	Passenger Presence Module																																																								
L	2011	Terrain	Body	Instrument Cluster																																																								
L	2011	Terrain	Body	Radio																																																								
L	2011	Terrain	Body	Multimedia Player Interface Module																																																								
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																																									
L	2011	Terrain	Body	Liftgate Control Module																																																										
L	2011	Terrain	Body	Parking Assist Control Module																																																										
L	2011	Terrain	Body	Frontview Camera Module																																																										
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																																										
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																										
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2012	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2012	Terrain	Body	Body Control Module																																																										
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2012	Terrain	Body	Passenger Presence Module																																																										
L	2012	Terrain	Body	Instrument Cluster																																																										
L	2012	Terrain	Body	Radio																																																										
L	2012	Terrain	Body	Multimedia Player Interface Module																																																										
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2012	Terrain	Body	Liftgate Control Module																																																										
L	2012	Terrain	Body	Parking Assist Control Module																																																										
L	2012	Terrain	Body	Frontview Camera Module																																																										
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																																										
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2013	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2013	Terrain	Chassis	Power Steering Control Module																																																										
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																																										
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2013	Terrain	Body	Passenger Presence Module																																																										
L	2013	Terrain	Body	Instrument Cluster																																																										
L	2013	Terrain	Body	Radio																																																										
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2013	Terrain	Body	Liftgate Control Module																																																										
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																										
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																										
L	2013	Terrain	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2013	Terrain	Body	Frontview Camera Module																																																									
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																									
L	2014	Terrain	Chassis	Electronic Brake Control Module																																																									
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2014	Terrain	Chassis	Power Steering Control Module																																																									
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																																									
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																									
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2014	Terrain	Body	Passenger Presence Module																																																									
L	2014	Terrain	Body	Instrument Cluster																																																									
L	2014	Terrain	Body	Radio																																																									
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																									
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																									
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																																									
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																																									
L	2014	Terrain	Body	Liftgate Control Module																																																									
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																									
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																									
L	2014	Terrain	Body	Parking Assist Control Module																																																									
L	2014	Terrain	Body	Frontview Camera Module																																																									
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																									
L	2015	Terrain	Chassis	Electronic Brake Control Module																																																									
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2015	Terrain	Chassis	Power Steering Control Module																																																									
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																																									
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																									
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2015	Terrain	Body	Passenger Presence Module																																																									
L	2015	Terrain	Body	Instrument Cluster																																																									
L	2015	Terrain	Body	Radio																																																									
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																																									
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																																									
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																																									
L	2015	Terrain	Body	Liftgate Control Module																																																									
L	2015	Terrain	Body	Seat Memory Control Module																																																									
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																									
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																									
L	2015	Terrain	Body	Parking Assist Control Module																																																									
L	2015	Terrain	Body	Frontview Camera Module																																																									
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																									
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																									
L	2016	Terrain	Chassis	Electronic Brake Control Module																																																									
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2016	Terrain	Chassis	Power Steering Control Module																																																									
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																																									
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																									
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2016	Terrain	Body	Passenger Presence Module																																																									
L	2016	Terrain	Body	Instrument Cluster																																																									
L	2016	Terrain	Body	Radio																																																									
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																																									
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																									
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																																									
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																																									
L	2016	Terrain	Body	Liftgate Control Module																																																									
L	2016	Terrain	Body	Seat Memory Control Module																																																									
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																									
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																									
L	2016	Terrain	Body	Parking Assist Control Module																																																									
L	2016	Terrain	Body	Frontview Camera Module																																																									
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
M	2004	ALL	Chassis	4WAL 3 Sensor																																																									
M	2004	ALL	Body	Body Control Module																																					V		V																		
M	2004	ALL	Body	Instrument Panel Cluster																																					V	V	V																		
M	2004	ALL	Body	Supplemental Inflatable Restraint																																					V	V																		
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																		
M	2005	ALL	Chassis	4WAL 3 Sensor																																																									
M	2005	ALL	Body	Body Control Module																																					V		V																		
M	2005	ALL	Body	Instrument Panel Cluster																																					V	V	V																		
M	2005	ALL	Body	Supplemental Inflatable Restraint																																					V	V																		
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module													V	V																																										
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module													V	V																																										
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module													V	V																																										
P	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																				V
P	2007	ALL	Body	Theft Deterrent Module																																					V																			
R	2007	ALL	Powertrain	Engine Control Module																											V		V	V																										
R	2007	ALL	Powertrain	Transmission Control Module																																V																								
R	2007	ALL	Chassis	Electronic Brake Control Module																																			V																				
R	2007	ALL	Body	Body Control Module			V																																			V	V																	
R	2007	ALL	Body	Digital Radio Receiver																																																								
R	2007	ALL	Body	Driver Door Switch																																					V	V	V																	
R	2007	ALL	Body	Head Up Display																																																								
R	2007	ALL	Body	Heated Seat Module																																																								
R	2007	ALL	Body	HVAC Control Module Auto																																						V		V																	
R	2007	ALL	Body	HVAC Control Module Manual																																						V		V																	
R	2007	ALL	Body	Instrument Panel Cluster																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2007	ALL	Body	Lift Gate Module																																					V																			
R	2007	ALL	Body	Park Assist Module																																																							
R	2007	ALL	Body	Passenger Door Switch																																					V	V	V																	
R	2007	ALL	Body	Passenger Presence System																																					V																			
R	2007	ALL	Body	Radio																																																							
R	2007	ALL	Body	Rear HVAC/RSA																																																							
R	2007	ALL	Body	Rollover Sensor																																																							
R	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																			
R	2007	ALL	Body	Theft Deterrent Module																																																							
R	2008	ALL	Powertrain	Engine Control Module																											V		V	V																											
R	2008	ALL	Powertrain	Transmission Control Module																																V																									
R	2008	ALL	Chassis	Electronic Brake Control Module																																			V																					
R	2008	ALL	Body	Body Control Module			V																																			V	V																	
R	2008	ALL	Body	Digital Radio Receiver																																																							
R	2008	ALL	Body	Driver Door Switch																																					V	V	V																	
R	2008	ALL	Body	Head Up Display																																																							
R	2008	ALL	Body	Heated Seat Module																																																							
R	2008	ALL	Body	HVAC Control Module Auto																																						V		V																	
R	2008	ALL	Body	HVAC Control Module Manual																																						V		V																	
R	2008	ALL	Body	Instrument Panel Cluster																																																							
R	2008	ALL	Body	Lift Gate Module																																					V																			
R	2008	ALL	Body	Park Assist Module																																																							
R	2008	ALL	Body	Passenger Door Switch																																					V	V	V																	
R	2008	ALL	Body	Passenger Presence System																																					V																			
R	2008	ALL	Body	Radio																																																							
R	2008	ALL	Body	Rear HVAC/RSA																																																							
R	2008	ALL	Body	Rollover Sensor																																																							
R	2008	ALL	Body	Supplemental Inflatable Restraint																																					V																			
R	2008	ALL	Body	Theft Deterrent Module																																																							
R	2009	ALL	Powertrain	Engine Control Module																											V		V	V																											
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																							
R	2009	ALL	Powertrain	Transmission Control Module																																V																									
R	2009	ALL	Chassis	Electronic Brake Control Module																																			V																			
R	2009	ALL	Body	Body Control Module			V																																			V	V																	
R	2009	ALL	Body	Digital Radio Receiver																																																							
R	2009	ALL	Body	Driver Door Switch																																					V	V	V																	
R	2009	ALL	Body	Head Up Display																																																							
R	2009	ALL	Body	Heated Seat Module																																																							
R	2009	ALL	Body	HVAC Control Module Auto																																						V		V																	
R	2009	ALL	Body	HVAC Control Module Manual																																						V		V																	
R	2009	ALL	Body	Instrument Panel Cluster																																																							
R	2009	ALL	Body	Lift Gate Module																																					V																			
R	2009	ALL	Body	Park Assist Module																																																							
R	2009	ALL	Body	Passenger Door Switch																																					V	V	V																	
R	2009	ALL	Body	Passenger Presence System																																					V																			
R	2009	ALL	Body	Radio																																																							
R	2009	ALL	Body	Rear HVAC/RSA																																																							
R	2009	ALL	Body	Rollover Sensor																																																							
R	2009	ALL	Body	Supplemental Inflatable Restraint																																					V																			
R	2009	ALL	Body	Theft Deterrent Module																																																							
R	2010	ALL	Powertrain	Engine Control Module																											V	V	V	V																											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2010	ALL	Powertrain	Transmission Control Module																																V	V																						
R	2010	ALL	Chassis	Electronic Brake Control Module																																		V																					
R	2010	ALL	Body	Body Control Module			V																																			V	V																
R	2010	ALL	Body	Digital Radio Receiver																																																						
R	2010	ALL	Body	Driver Door Switch																																				V	V	V																	
R	2010	ALL	Body	Head Up Display																																																						
R	2010	ALL	Body	Heated Seat Module																																																						
R	2010	ALL	Body	HVAC Control Module Auto																																						V		V															
R	2010	ALL	Body	HVAC Control Module Manual																																						V		V															
R	2010	ALL	Body	Instrument Panel Cluster																																																						
R	2010	ALL	Body	Lift Gate Module																																				V																			
R	2010	ALL	Body	Park Assist Module																																																						
R	2010	ALL	Body	Passenger Door Switch																																				V	V	V																	
R	2010	ALL	Body	Passenger Presence System																																				V																			
R	2010	ALL	Body	Radio																																																						
R	2010	ALL	Body	Rear HVAC/RSA																																																						
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																						
R	2010	ALL	Body	Theft Deterrent Module																																																						
R	2011	ALL	Powertrain	Engine Control Module																											V	V	V	V																										
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																						
R	2011	ALL	Powertrain	Transmission Control Module																																V	V																						
R	2011	ALL	Chassis	Electronic Brake Control Module																																		V																					
R	2011	ALL	Body	Body Control Module			V																																			V	V																
R	2011	ALL	Body	Digital Radio Receiver																																																						
R	2011	ALL	Body	Driver Door Switch																																				V	V	V																	
R	2011	ALL	Body	Head Up Display																																																						
R	2011	ALL	Body	Heated Seat Module																																																						
R	2011	ALL	Body	HVAC Control Module Auto																																						V		V															
R	2011	ALL	Body	HVAC Control Module Manual																																						V		V															
R	2011	ALL	Body	Instrument Panel Cluster																																																						
R	2011	ALL	Body	Lift Gate Module																																				V																			
R	2011	ALL	Body	Park Assist Module																																																						
R	2011	ALL	Body	Passenger Door Switch																																				V	V	V																	
R	2011	ALL	Body	Passenger Presence System																																				V																			
R	2011	ALL	Body	Radio																																																						
R	2011	ALL	Body	Rear HVAC/RSA																																																						
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																						
R	2011	ALL	Body	Theft Deterrent Module																																																						
R	2012	ALL	Powertrain	Engine Control Module																											V	V	V	V																										
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																						
R	2012	ALL	Powertrain	Transmission Control Module																																V	V																						
R	2012	ALL	Chassis	Electronic Brake Control Module																																		V																					
R	2012	ALL	Body	Body Control Module			V																																			V	V																
R	2012	ALL	Body	Digital Radio Receiver																																																						
R	2012	ALL	Body	Driver Door Switch																																				V	V	V																	
R	2012	ALL	Body	Head Up Display																																																						
R	2012	ALL	Body	Heated Seat Module																																																						
R	2012	ALL	Body	HVAC Control Module Auto																																						V		V															
R	2012	ALL	Body	HVAC Control Module Manual																																						V		V															
R	2012	ALL	Body	Instrument Panel Cluster																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2012	ALL	Body	Lift Gate Module																																					V																			
R	2012	ALL	Body	Park Assist Module																																																							
R	2012	ALL	Body	Passenger Door Switch																																					V	V	V																	
R	2012	ALL	Body	Passenger Presence System																																					V																			
R	2012	ALL	Body	Radio																																																							
R	2012	ALL	Body	Rear HVAC/RSA																																																							
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																							
R	2012	ALL	Body	Theft Deterrent Module																																																							
R	2013	ALL	Powertrain	Engine Control Module																											V	V	V	V																											
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																							
R	2013	ALL	Powertrain	Transmission Control Module																																	V	V																						
R	2013	ALL	Chassis	Electronic Brake Control Module																																			V																				
R	2013	ALL	Body	Body Control Module			V																																			V	V																	
R	2013	ALL	Body	Digital Radio Receiver																																																							
R	2013	ALL	Body	Driver Door Switch																																					V	V	V																	
R	2013	ALL	Body	Head Up Display																																																							
R	2013	ALL	Body	Heated Seat Module																																																							
R	2013	ALL	Body	HVAC Control Module Auto																																						V		V																
R	2013	ALL	Body	HVAC Control Module Manual																																						V		V																
R	2013	ALL	Body	Instrument Panel Cluster																																																							
R	2013	ALL	Body	Left Side Object Detection Module																																																							
R	2013	ALL	Body	Lift Gate Module																																					V																			
R	2013	ALL	Body	Park Assist Module																																																							
R	2013	ALL	Body	Passenger Door Switch																																					V	V	V																	
R	2013	ALL	Body	Passenger Presence System																																					V																			
R	2013	ALL	Body	Radio																																																							
R	2013	ALL	Body	Rear HVAC/RSA																																																							
R	2013	ALL	Body	Right Side Object Detection Module																																																							
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																							
R	2013	ALL	Body	Theft Deterrent Module																																																							
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																							
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																							
R	2014	Acadia	Powertrain	Chassis Control Module																																																							
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																							
R	2014	Acadia	Chassis	Electronic Brake Control Module																																																							
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																							
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																							
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
R	2014	Acadia	Body	Passenger Presence Module																																																							
R	2014	Acadia	Body	Instrument Cluster																																																							
R	2014	Acadia	Body	Head-Up Display Module																																																							
R	2014	Acadia	Body	Radio																																																							
R	2014	Acadia	Body	Rear Audio Control Module																																																							
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																							
R	2014	Acadia	Body	Personal Audio Link Control Module																																																							
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																							
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																							
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																							
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																							
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																							
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2014	Acadia	Body	Liftgate Control Module																																																								
R	2014	Acadia	Body	Seat Memory Control Module																																																								
R	2014	Acadia	Body	Front Seat Heating Control Module																																																								
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																								
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																								
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																								
R	2014	Acadia	Body	Parking Assist Control Module																																																								
R	2014	Acadia	Body	Frontview Camera Module																																																								
R	2014	Acadia	Body	Theft Deterrent Module																																																								
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																								
R	2015	Acadia	Chassis	Electronic Brake Control Module																																																								
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																								
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																								
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2015	Acadia	Body	Passenger Presence Module																																																								
R	2015	Acadia	Body	Instrument Cluster																																																								
R	2015	Acadia	Body	Head-Up Display Module																																																								
R	2015	Acadia	Body	Radio																																																								
R	2015	Acadia	Body	Rear Audio Control Module																																																								
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																								
R	2015	Acadia	Body	Personal Audio Link Control Module																																																								
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																								
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																								
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																								
R	2015	Acadia	Body	Liftgate Control Module																																																								
R	2015	Acadia	Body	Seat Memory Control Module																																																								
R	2015	Acadia	Body	Front Seat Heating Control Module																																																								
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																								
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																								
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																								
R	2015	Acadia	Body	Parking Assist Control Module																																																								
R	2015	Acadia	Body	Frontview Camera Module																																																								
R	2015	Acadia	Body	Theft Deterrent Module																																																								
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																								
R	2016	Acadia	Chassis	Electronic Brake Control Module																																																								
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																								
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																								
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2016	Acadia	Body	Passenger Presence Module																																																								
R	2016	Acadia	Body	Instrument Cluster																																																								
R	2016	Acadia	Body	Head-Up Display Module																																																								
R	2016	Acadia	Body	Radio																																																								
R	2016	Acadia	Body	Rear Audio Control Module																																																								
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
R	2016	Acadia	Body	Personal Audio Link Control Module																																																									
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																										
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Acadia	Body	Liftgate Control Module																																																										
R	2016	Acadia	Body	Seat Memory Control Module																																																										
R	2016	Acadia	Body	Front Seat Heating Control Module																																																										
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																										
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																										
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																										
R	2016	Acadia	Body	Parking Assist Control Module																																																										
R	2016	Acadia	Body	Frontview Camera Module																																																										
R	2016	Acadia	Body	Theft Deterrent Module																																																										
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																											
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																			
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																										
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Sonoma	Body	Body Control Module																																					V		V																			
S	2004	Sonoma	Body	Instrument Panel Cluster																																					V	V	V																			
S	2004	Sonoma	Body	Base Radio																																																										
S	2004	Sonoma	Body	Uplevel Radio																																																										
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																					V	V																				
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module													V	V	V																																										
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																V	V	V		V	V	V																																			
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module													V	V	V																																										
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																V	V	V		V	V	V																																			
S	2004	Canyon	Chassis	ABS Without Traction Control																																																										
S	2004	Canyon	Chassis	ABS With Traction Control																																																										
S	2004	Canyon	Body	Body Control Module																																					V	V	V																			
S	2004	Canyon	Body	Instrument Panel Cluster																																					V	V																			
S	2004	Canyon	Body	OnStar																																																									
S	2004	Canyon	Body	Base Radio																																																									
S	2004	Canyon	Body	Uplevel Radio																																																									
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																					V																				V
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																										
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																			
S	2004	Envoy	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy	Body	Amplifier (Bose)																																																										
S	2004	Envoy	Body	Body Control Module																																																										
S	2004	Envoy	Body	Driver Door Module																																					V	V	V																			
S	2004	Envoy	Body	Driver Seat Module																																																										
S	2004	Envoy	Body	Heating and Air Conditioning Auto																																																										
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy	Body	Instrument Panel Cluster																																																										
S	2004	Envoy	Body	Lift Gate Module																																																										
S	2004	Envoy	Body	OnStar																																																										
S	2004	Envoy	Body	Passenger Door Module																																					V	V	V																			

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2004	Envoy	Body	Uplevel Radio																																																								
S	2004	Envoy	Body	Navigation Radio																																																								
S	2004	Envoy	Body	Rear Seat Audio																																																								
S	2004	Envoy	Body	Rear Seat Entertainment																																																								
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																					V	V																		
S	2004	Envoy	Body	Vehicle Theft Deterrent																																					V																			
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module													V	V																																										
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																V	V	V		V	V	V																																		
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																								
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																								
S	2004	Envoy XL	Body	Amplifier (Bose)																																																								
S	2004	Envoy XL	Body	Body Control Module																																																								
S	2004	Envoy XL	Body	Driver Door Module																																					V	V	V																	
S	2004	Envoy XL	Body	Driver Seat Module																																																								
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																								
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																								
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																								
S	2004	Envoy XL	Body	Lift Gate Module																																																								
S	2004	Envoy XL	Body	OnStar																																																								
S	2004	Envoy XL	Body	Passenger Door Module																																					V	V	V																	
S	2004	Envoy XL	Body	Uplevel Radio																																																								
S	2004	Envoy XL	Body	Navigation Radio																																																								
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																								
S	2004	Envoy XL	Body	Rear HVAC Manual																																																								
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																								
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																					V	V																		
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																					V																			
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module													V	V																																										
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																V	V	V		V	V	V																																		
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																								
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																								
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																								
S	2004	Envoy XUV	Body	Body Control Module																																																								
S	2004	Envoy XUV	Body	Driver Door Module																																					V	V	V																	
S	2004	Envoy XUV	Body	Driver Seat Module																																																								
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																								
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																								
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																								
S	2004	Envoy XUV	Body	Lift Gate Module																																																								
S	2004	Envoy XUV	Body	OnStar																																																								
S	2004	Envoy XUV	Body	Passenger Door Module																																					V	V	V																	
S	2004	Envoy XUV	Body	Uplevel Radio																																																								
S	2004	Envoy XUV	Body	Navigation Radio																																																								
S	2004	Envoy XUV	Body	Rear Seat Audio																																																								
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																					V	V																		
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																					V																		
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																									
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																	
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																								
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																							
S	2004	Jimmy	Body	Body Control Module																																					V		V																	
S	2004	Jimmy	Body	Heating and Air Conditioning																																																							
S	2004	Jimmy	Body	Instrument Panel Cluster																																					V	V	V																	
S	2004	Jimmy	Body	Memory Seat Module																																					V	V	V																	
S	2004	Jimmy	Body	Base Radio																																																							
S	2004	Jimmy	Body	Uplevel Radio																																																							
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																					V	V																		
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module													V	V	V																																								
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																V	V	V		V	V	V																																	
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module													V	V	V																																								
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																V	V	V		V	V	V																																	
S	2005	Canyon	Chassis	ABS Without Traction Control																																																							
S	2005	Canyon	Chassis	ABS With Traction Control																																																							
S	2005	Canyon	Body	Body Control Module																																					V	V	V																	
S	2005	Canyon	Body	Instrument Panel Cluster																																					V	V																		
S	2005	Canyon	Body	Base Radio																																																							
S	2005	Canyon	Body	Uplevel Radio																																																							
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																					V																			V
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																																							
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																							
S	2005	Envoy	Chassis	ABS Without Traction Control																																																							
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																							
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																							
S	2005	Envoy	Body	Body Control Module																																																							
S	2005	Envoy	Body	Disc Player and Video Display																																																							
S	2005	Envoy	Body	Driver Door Module																																					V	V	V																	
S	2005	Envoy	Body	Driver Seat Module																																																							
S	2005	Envoy	Body	Heating and Air Conditioning Auto																																																							
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																																							
S	2005	Envoy	Body	Instrument Panel Cluster																																																							
S	2005	Envoy	Body	Lift Gate Module																																																							
S	2005	Envoy	Body	Passenger Door Module																																					V	V	V																	
S	2005	Envoy	Body	Passenger Presence System																																																							
S	2005	Envoy	Body	Uplevel Radio																																																							
S	2005	Envoy	Body	Navigation Radio																																																							
S	2005	Envoy	Body	Rear Seat Audio																																																							
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																					V																			V
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																																							
S	2005	Envoy	Body	Vehicle Theft Deterrent																																					V																			
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																						
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																						
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																					
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																					
S	2005	Envoy XL	Body	Body Control Module																																																					
S	2005	Envoy XL	Body	Disc Player and Video Display																																																					
S	2005	Envoy XL	Body	Driver Door Module																																					V	V	V																
S	2005	Envoy XL	Body	Driver Seat Module																																																					
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																					
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																					
S	2005	Envoy XL	Body	Instrument Panel Cluster																																																					
S	2005	Envoy XL	Body	Lift Gate Module																																																					
S	2005	Envoy XL	Body	Passenger Door Module																																					V	V	V																
S	2005	Envoy XL	Body	Passenger Presence System																																																					
S	2005	Envoy XL	Body	Uplevel Radio																																																					
S	2005	Envoy XL	Body	Navigation Radio																																																					
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																					
S	2005	Envoy XL	Body	Rear HVAC Manual																																																					
S	2005	Envoy XL	Body	Rear Seat Audio																																																					
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																					V																	V
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																					
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																					V																	
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																						
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																								
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																						
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																					
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																					
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																					
S	2005	Envoy XUV	Body	Body Control Module																																																					
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																					
S	2005	Envoy XUV	Body	Driver Door Module																																					V	V	V																
S	2005	Envoy XUV	Body	Driver Seat Module																																																					
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																					
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																					
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																																					
S	2005	Envoy XUV	Body	Lift Gate Module																																																					
S	2005	Envoy XUV	Body	Passenger Door Module																																					V	V	V																
S	2005	Envoy XUV	Body	Passenger Presence System																																																					
S	2005	Envoy XUV	Body	Uplevel Radio																																																					
S	2005	Envoy XUV	Body	Navigation Radio																																																					
S	2005	Envoy XUV	Body	Rear Seat Audio																																																					
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																					V																	V
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																					
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																					V																	
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																								
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																					
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																					
S	2005	Jimmy	Body	Body Control Module																																					V		V															
S	2005	Jimmy	Body	Heating and Air Conditioning																																																					

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2005	Jimmy	Body	Instrument Panel Cluster																																					V	V	V																
S	2005	Jimmy	Body	Memory Seat Module																																					V	V	V																
S	2005	Jimmy	Body	Base Radio																																																						
S	2005	Jimmy	Body	Uplevel Radio																																																						
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																					V	V																	
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																									
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																	
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																							
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																						
S	2005	Sonoma	Body	Body Control Module																																					V		V																
S	2005	Sonoma	Body	Instrument Panel Cluster																																					V	V	V																
S	2005	Sonoma	Body	Base Radio																																																						
S	2005	Sonoma	Body	Uplevel Radio																																																						
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																					V	V																	
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module													V	V	V																																								
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																V	V	V		V	V	V																																	
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module													V	V	V																																								
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																V	V	V		V	V	V																																	
S	2006	Canyon	Chassis	ABS Without Traction Control																																																						
S	2006	Canyon	Chassis	ABS With Traction Control																																																						
S	2006	Canyon	Body	Body Control Module																																					V	V	V																
S	2006	Canyon	Body	Instrument Panel Cluster																																					V	V																	
S	2006	Canyon	Body	Passenger Presence System																																																						
S	2006	Canyon	Body	Base Radio																																																						
S	2006	Canyon	Body	Uplevel Radio																																																						
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																					V																		V
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																																						
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																								
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																						
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																									
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V													V																						
S	2006	Envoy	Chassis	ABS/TCS/VSES																																																						
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																						
S	2006	Envoy	Body	Body Control Module																																					V	V	V																
S	2006	Envoy	Body	Disc Player and Video Display																																																						
S	2006	Envoy	Body	Driver Door Module																																					V	V	V																
S	2006	Envoy	Body	Driver Seat Module																																																						
S	2006	Envoy	Body	Heating and Air Conditioning Auto																																																						
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																																						
S	2006	Envoy	Body	Instrument Panel Cluster																																																						
S	2006	Envoy	Body	Lift Gate Module																																																						
S	2006	Envoy	Body	Passenger Door Module																																					V	V	V																
S	2006	Envoy	Body	Passenger Presence System																																																						
S	2006	Envoy	Body	Uplevel Radio																																																						
S	2006	Envoy	Body	Navigation Radio																																																						
S	2006	Envoy	Body	Rear Seat Audio																																																						
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																					V																		V
S	2006	Envoy	Body	Vehicle Theft Deterrent																																					V																		
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																											
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																								
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																									
S	2006	Envoy XL	Body	Body Control Module																																				V	V	V																			
S	2006	Envoy XL	Body	Disc Player and Video Display																																																									
S	2006	Envoy XL	Body	Driver Door Module																																				V	V	V																			
S	2006	Envoy XL	Body	Driver Seat Module																																																									
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																									
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																									
S	2006	Envoy XL	Body	Instrument Panel Cluster																																																									
S	2006	Envoy XL	Body	Lift Gate Module																																																									
S	2006	Envoy XL	Body	Passenger Door Module																																				V	V	V																			
S	2006	Envoy XL	Body	Passenger Presence System																																																									
S	2006	Envoy XL	Body	Uplevel Radio																																																									
S	2006	Envoy XL	Body	Navigation Radio																																																									
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																									
S	2006	Envoy XL	Body	Rear HVAC Manual																																																									
S	2006	Envoy XL	Body	Rear Seat Audio																																																									
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																				V																					V
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																				V																				
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																									
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V		V	V																											
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V																																		
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V		V	V																											
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V																																		
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																								
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																								
S	2007	Canyon	Body	Body Control Module																																				V	V	V																			
S	2007	Canyon	Body	Digital Radio Receiver																																																									
S	2007	Canyon	Body	Generator Battery Control Module																																																									
S	2007	Canyon	Body	Instrument Panel Cluster																																				V	V																				
S	2007	Canyon	Body	Passenger Presence System																																																									
S	2007	Canyon	Body	Base Radio																																																									
S	2007	Canyon	Body	Uplevel Radio																																																									
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																				V																					V
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																																									
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																											V		V	V																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																											V		V	V																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																V	V	V		V	V	V																																		
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																											
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V																																				
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																											
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V																																				
S	2007	Envoy	Chassis	Electronic Brake Control Module																																																									
S	2007	Envoy	Body	Body Control Module																																				V	V	V																			
S	2007	Envoy	Body	Digital Radio Receiver																																																									
S	2007	Envoy	Body	Disc Player and Video Display																																																									
S	2007	Envoy	Body	Driver Door Module																																				V	V	V																			

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2007	Envoy	Body	Driver Seat Module																																																								
S	2007	Envoy	Body	Generator Battery Control Module																																																								
S	2007	Envoy	Body	HVAC Control Module Auto																																																								
S	2007	Envoy	Body	HVAC Control Module Manual																																																								
S	2007	Envoy	Body	Instrument Panel Cluster																																																								
S	2007	Envoy	Body	Lift Gate Module																																					V																			
S	2007	Envoy	Body	Passenger Door Module																																					V	V	V																	
S	2007	Envoy	Body	Passenger Presence System																																																								
S	2007	Envoy	Body	Uplevel Radio																																																								
S	2007	Envoy	Body	Navigation Radio																																																								
S	2007	Envoy	Body	Rear Seat Audio																																																								
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																					V																			V
S	2007	Envoy	Body	Theft Deterrent Module																																					V																			
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																																								
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																										
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V																																				
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																										
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V																																				
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																								
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																								
S	2008	Canyon	Body	Body Control Module																																					V	V	V																	
S	2008	Canyon	Body	Digital Radio Receiver																																																								
S	2008	Canyon	Body	Generator Battery Control Module																																																								
S	2008	Canyon	Body	Instrument Panel Cluster																																					V	V																		
S	2008	Canyon	Body	Passenger Presence System																																																								
S	2008	Canyon	Body	Base Radio																																																								
S	2008	Canyon	Body	Uplevel Radio																																																								
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																					V																			V
S	2008	Canyon	Body	Theft Deterrent Module																																					V																			
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																																								
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																											V	V	V	V																										
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V																																				
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V																																				
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																										
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V																																				
S	2008	Envoy	Chassis	Electronic Brake Control Module																																																								
S	2008	Envoy	Body	Body Control Module																																					V	V	V																	
S	2008	Envoy	Body	Digital Radio Receiver																																																								
S	2008	Envoy	Body	Disc Player and Video Display																																																								
S	2008	Envoy	Body	Driver Door Module																																					V	V	V																	
S	2008	Envoy	Body	Driver Seat Module																																																								
S	2008	Envoy	Body	Generator Battery Control Module																																																								
S	2008	Envoy	Body	HVAC Control Module Auto																																																								
S	2008	Envoy	Body	HVAC Control Module Manual																																																								
S	2008	Envoy	Body	Instrument Panel Cluster																																																								
S	2008	Envoy	Body	Lift Gate Module																																					V																			
S	2008	Envoy	Body	Passenger Door Module																																					V	V	V																	
S	2008	Envoy	Body	Passenger Presence System																																																								
S	2008	Envoy	Body	Uplevel Radio																																																								
S	2008	Envoy	Body	Navigation Radio																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2008	Envoy	Body	Rear Seat Audio																																																								
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																					V																				V
S	2008	Envoy	Body	Theft Deterrent Module																																					V																			
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																																								
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																											
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V											V																								
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																											
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																								
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																											V		V	V																											
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																V	V	V		V	V	V											V																								
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																								
S	2009	Canyon	Chassis	Electronic Brake Control Module																																			V																						
S	2009	Canyon	Body	Body Control Module																																					V	V	V																		
S	2009	Canyon	Body	Digital Radio Receiver																																																								
S	2009	Canyon	Body	Generator Battery Control Module																																																								
S	2009	Canyon	Body	Instrument Panel Cluster																																					V	V																			
S	2009	Canyon	Body	Passenger Presence System																																																								
S	2009	Canyon	Body	Base Radio																																																								
S	2009	Canyon	Body	Uplevel Radio																																																								
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																					V																				V
S	2009	Canyon	Body	Theft Deterrent Module																																					V																			
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																											V	V	V	V																											
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V											V																								
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																								
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																											
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V	V	V											V																								
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																											
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V	V	V											V																								
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																								
S	2009	Envoy	Chassis	Electronic Brake Control Module																																																								
S	2009	Envoy	Body	Body Control Module																																					V	V	V																		
S	2009	Envoy	Body	Digital Radio Receiver																																																								
S	2009	Envoy	Body	Disc Player and Video Display																																																								
S	2009	Envoy	Body	Driver Door Module																																					V	V	V																		
S	2009	Envoy	Body	Driver Seat Module																																																								
S	2009	Envoy	Body	Generator Battery Control Module																																																								
S	2009	Envoy	Body	HVAC Control Module Auto																																																								
S	2009	Envoy	Body	HVAC Control Module Manual																																																								
S	2009	Envoy	Body	Instrument Panel Cluster																																																								
S	2009	Envoy	Body	Lift Gate Module																																					V																			
S	2009	Envoy	Body	Passenger Door Module																																					V	V	V																		
S	2009	Envoy	Body	Passenger Presence System																																																								
S	2009	Envoy	Body	Uplevel Radio																																																								
S	2009	Envoy	Body	Navigation Radio																																																								
S	2009	Envoy	Body	Rear Seat Audio																																																								
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																					V																				V
S	2009	Envoy	Body	Theft Deterrent Module																																					V																			
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																											

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V											V																						
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																						
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																						
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																						
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																											V		V	V																									
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																V	V	V		V	V	V											V																						
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																						
S	2010	ALL	Chassis	Electronic Brake Control Module																																			V																				
S	2010	ALL	Body	Body Control Module																																				V	V	V																	
S	2010	ALL	Body	Digital Radio Receiver																																																						
S	2010	ALL	Body	Generator Battery Control Module																																																						
S	2010	ALL	Body	Instument Panel Cluster																																				V	V																	
S	2010	ALL	Body	Passenger Presence System																																																						
S	2010	ALL	Body	Personal Audio Link Module																																																						
S	2010	ALL	Body	Base Radio																																																						
S	2010	ALL	Body	Uplevel Radio																																																						
S	2010	ALL	Body	Supplemental Inflatable Restraint																																				V																		V
S	2010	ALL	Body	Theft Deterrent Module																																				V																		
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																						
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																								
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																	
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																						
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																						
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																						
T	2004	Sonoma	Body	Body Control Module																																				V		V																
T	2004	Sonoma	Body	Instrument Panel Cluster																																				V	V	V																
T	2004	Sonoma	Body	Base Radio																																																						
T	2004	Sonoma	Body	Uplevel Radio																																																						
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																				V	V																	
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module													V	V	V																																							
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																V	V	V		V	V	V																																	
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module													V	V	V																																							
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																V	V	V		V	V	V																																	
T	2004	Canyon	Chassis	ABS Without Traction Control																																																						
T	2004	Canyon	Chassis	ABS With Traction Control																																																						
T	2004	Canyon	Body	Body Control Module																																				V	V	V																
T	2004	Canyon	Body	Instrument Panel Cluster																																				V	V																	
T	2004	Canyon	Body	OnStar																																																						
T	2004	Canyon	Body	Base Radio																																																						
T	2004	Canyon	Body	Uplevel Radio																																																						
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																				V																		V
T	2004	Canyon	Body	Instrument Panel Cluster																																				V	V																	
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																							
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																						
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																						
T	2004	Envoy	Chassis	ABS Without Traction Control																																																						
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																						
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																						
T	2004	Envoy	Body	Amplifier (Bose)																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2004	Envoy	Body	Body Control Module																																																									
T	2004	Envoy	Body	Driver Door Module																																					V	V	V																		
T	2004	Envoy	Body	Driver Seat Module																																																								
T	2004	Envoy	Body	Heating and Air Conditioning Auto																																																								
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																																								
T	2004	Envoy	Body	Instrument Panel Cluster																																																								
T	2004	Envoy	Body	Lift Gate Module																																																								
T	2004	Envoy	Body	OnStar																																																								
T	2004	Envoy	Body	Passenger Door Module																																					V	V	V																		
T	2004	Envoy	Body	Uplevel Radio																																																								
T	2004	Envoy	Body	Navigation Radio																																																								
T	2004	Envoy	Body	Rear Seat Audio																																																								
T	2004	Envoy	Body	Rear Seat Entertainment																																																								
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																					V	V																		
T	2004	Envoy	Body	Vehicle Theft Deterrent																																					V																			
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module													V	V																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																V	V	V		V	V	V																																		
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																								
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																								
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																								
T	2004	Envoy XL	Body	Amplifier (Bose)																																																								
T	2004	Envoy XL	Body	Body Control Module																																																								
T	2004	Envoy XL	Body	Driver Door Module																																					V	V	V																		
T	2004	Envoy XL	Body	Driver Seat Module																																																								
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																								
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																								
T	2004	Envoy XL	Body	Instrument Panel Cluster																																																								
T	2004	Envoy XL	Body	Lift Gate Module																																																								
T	2004	Envoy XL	Body	OnStar																																																								
T	2004	Envoy XL	Body	Passenger Door Module																																					V	V	V																		
T	2004	Envoy XL	Body	Uplevel Radio																																																								
T	2004	Envoy XL	Body	Navigation Radio																																																								
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																								
T	2004	Envoy XL	Body	Rear HVAC Manual																																																								
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																								
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																					V	V																		
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																					V																		
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module													V	V																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																V	V	V		V	V	V																																		
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																								
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																								
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																								
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2004	Envoy XUV	Body	Body Control Module																																																									
T	2004	Envoy XUV	Body	Driver Door Module																																					V	V	V																		
T	2004	Envoy XUV	Body	Driver Seat Module																																																								
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																								
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																								
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																																								
T	2004	Envoy XUV	Body	Lift Gate Module																																																								
T	2004	Envoy XUV	Body	OnStar																																																								
T	2004	Envoy XUV	Body	Passenger Door Module																																					V	V	V																		
T	2004	Envoy XUV	Body	Uplevel Radio																																																								
T	2004	Envoy XUV	Body	Navigation Radio																																																								
T	2004	Envoy XUV	Body	Rear Seat Audio																																																								
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																								
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																					V	V																		
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																					V																		
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																									
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																	
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																								
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																								
T	2004	Jimmy	Body	Body Control Module																																					V		V																		
T	2004	Jimmy	Body	Heating and Air Conditioning																																																								
T	2004	Jimmy	Body	Instrument Panel Cluster																																					V	V	V																		
T	2004	Jimmy	Body	Memory Seat Module																																					V	V	V																		
T	2004	Jimmy	Body	Base Radio																																																								
T	2004	Jimmy	Body	Uplevel Radio																																																								
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																					V	V																		
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module													V	V	V																																								
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																V	V	V		V	V	V																																	
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module													V	V	V																																								
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																V	V	V		V	V	V																																	
T	2005	Canyon	Chassis	ABS Without Traction Control																																																								
T	2005	Canyon	Chassis	ABS With Traction Control																																																								
T	2005	Canyon	Body	Body Control Module																																					V	V	V																		
T	2005	Canyon	Body	Instrument Panel Cluster																																					V	V																		
T	2005	Canyon	Body	Base Radio																																																								
T	2005	Canyon	Body	Uplevel Radio																																																								
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																					V																				V
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																																								
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																									
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																								
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable													V	V																																										
T	2005	Envoy	Chassis	ABS Without Traction Control																																																								
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																								
T	2005	Envoy	Body	Body Control Module																																																								
T	2005	Envoy	Body	Disc Player and Video Display																																																								
T	2005	Envoy	Body	Driver Door Module																																					V	V	V																		
T	2005	Envoy	Body	Driver Seat Module																																																								
T	2005	Envoy	Body	Heating and Air Conditioning Auto																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																																							
T	2005	Envoy	Body	Instrument Panel Cluster																																																							
T	2005	Envoy	Body	Lift Gate Module																																																							
T	2005	Envoy	Body	Passenger Door Module																																					V	V	V																	
T	2005	Envoy	Body	Passenger Presence System																																																							
T	2005	Envoy	Body	Uplevel Radio																																																							
T	2005	Envoy	Body	Navigation Radio																																																							
T	2005	Envoy	Body	Rear Seat Audio																																																							
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																					V																			V
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																																							
T	2005	Envoy	Body	Vehicle Theft Deterrent																																					V																			
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																								
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																							
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																							
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																							
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																							
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																							
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																							
T	2005	Envoy XL	Body	Body Control Module																																																							
T	2005	Envoy XL	Body	Disc Player and Video Display																																																							
T	2005	Envoy XL	Body	Driver Door Module																																					V	V	V																	
T	2005	Envoy XL	Body	Driver Seat Module																																																							
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																							
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																							
T	2005	Envoy XL	Body	Instrument Panel Cluster																																																							
T	2005	Envoy XL	Body	Lift Gate Module																																																							
T	2005	Envoy XL	Body	Passenger Door Module																																					V	V	V																	
T	2005	Envoy XL	Body	Passenger Presence System																																																							
T	2005	Envoy XL	Body	Uplevel Radio																																																							
T	2005	Envoy XL	Body	Navigation Radio																																																							
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																							
T	2005	Envoy XL	Body	Rear HVAC Manual																																																							
T	2005	Envoy XL	Body	Rear Seat Audio																																																							
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																					V																			V
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																							
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																					V																			
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																								
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																							
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																							
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																							
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																							
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																							
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																							
T	2005	Envoy XUV	Body	Body Control Module																																																							
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																							
T	2005	Envoy XUV	Body	Driver Door Module																																					V	V	V																	
T	2005	Envoy XUV	Body	Driver Seat Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																							
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																							
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																																							
T	2005	Envoy XUV	Body	Lift Gate Module																																																							
T	2005	Envoy XUV	Body	Passenger Door Module																																					V	V	V																	
T	2005	Envoy XUV	Body	Passenger Presence System																																																							
T	2005	Envoy XUV	Body	Uplevel Radio																																																							
T	2005	Envoy XUV	Body	Navigation Radio																																																							
T	2005	Envoy XUV	Body	Rear Seat Audio																																																							
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																					V																			V
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																							
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																					V																			
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																	
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																							
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																							
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																							
T	2005	Jimmy	Body	Body Control Module																																					V		V																	
T	2005	Jimmy	Body	Heating and Air Conditioning																																																							
T	2005	Jimmy	Body	Instrument Panel Cluster																																					V	V	V																	
T	2005	Jimmy	Body	Memory Seat Module																																					V	V	V																	
T	2005	Jimmy	Body	Base Radio																																																							
T	2005	Jimmy	Body	Uplevel Radio																																																							
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																					V	V																		
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module													V	V																																										
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V																																	
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																							
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																							
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																							
T	2005	Sonoma	Body	Body Control Module																																					V		V																	
T	2005	Sonoma	Body	Instrument Panel Cluster																																					V	V	V																	
T	2005	Sonoma	Body	Base Radio																																																							
T	2005	Sonoma	Body	Uplevel Radio																																																							
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																					V	V																		
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module													V	V	V																																								
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																V	V	V		V	V	V																																	
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module													V	V	V																																								
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																V	V	V		V	V	V																																	
T	2006	Canyon	Chassis	ABS Without Traction Control																																																						
T	2006	Canyon	Chassis	ABS With Traction Control																																																						
T	2006	Canyon	Body	Body Control Module																																					V	V	V																	
T	2006	Canyon	Body	Instrument Panel Cluster																																					V	V																		
T	2006	Canyon	Body	Passenger Presence System																																																						
T	2006	Canyon	Body	Base Radio																																																						
T	2006	Canyon	Body	Uplevel Radio																																																						
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																					V																			V
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																																						
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																								
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																						
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																						
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																						
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																									
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V													V																						
T	2006	Envoy	Chassis	ABS/TCS/VSES																																																						
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																						
T	2006	Envoy	Body	Body Control Module																																					V	V	V																
T	2006	Envoy	Body	Disc Player and Video Display																																																						
T	2006	Envoy	Body	Driver Door Module																																					V	V	V																
T	2006	Envoy	Body	Driver Seat Module																																																						
T	2006	Envoy	Body	Heating and Air Conditioning Auto																																																						
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																																						
T	2006	Envoy	Body	Instrument Panel Cluster																																																						
T	2006	Envoy	Body	Lift Gate Module																																																						
T	2006	Envoy	Body	Passenger Door Module																																					V	V	V																
T	2006	Envoy	Body	Passenger Presence System																																																						
T	2006	Envoy	Body	Uplevel Radio																																																						
T	2006	Envoy	Body	Navigation Radio																																																						
T	2006	Envoy	Body	Rear Seat Audio																																																						
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																					V																		V
T	2006	Envoy	Body	Vehicle Theft Deterrent																																					V																		
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																																						
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module													V	V	V																																								
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																	
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																						
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																									
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V													V																						
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																						
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																						
T	2006	Envoy XL	Body	Body Control Module																																					V	V	V																
T	2006	Envoy XL	Body	Disc Player and Video Display																																																						
T	2006	Envoy XL	Body	Driver Door Module																																					V	V	V																
T	2006	Envoy XL	Body	Driver Seat Module																																																						
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																						
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																						
T	2006	Envoy XL	Body	Instrument Panel Cluster																																																						
T	2006	Envoy XL	Body	Lift Gate Module																																																						
T	2006	Envoy XL	Body	Passenger Door Module																																					V	V	V																
T	2006	Envoy XL	Body	Passenger Presence System																																																						
T	2006	Envoy XL	Body	Uplevel Radio																																																						
T	2006	Envoy XL	Body	Navigation Radio																																																						
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																						
T	2006	Envoy XL	Body	Rear HVAC Manual																																																						
T	2006	Envoy XL	Body	Rear Seat Audio																																																						
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																					V																		V
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																					V																		
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																						
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V		V	V																									
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V																																	
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																						
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V		V	V																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V																																	
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																							
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																							
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																							
T	2007	Canyon	Body	Body Control Module																																					V	V	V																	
T	2007	Canyon	Body	Digital Radio Receiver																																																							
T	2007	Canyon	Body	Generator Battery Control Module																																																							
T	2007	Canyon	Body	Instrument Panel Cluster																																					V	V																		
T	2007	Canyon	Body	Passenger Presence System																																																							
T	2007	Canyon	Body	Base Radio																																																							
T	2007	Canyon	Body	Uplevel Radio																																																							
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																					V																			V
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																																							
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																											V		V	V																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V																																		
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																								
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																											V		V	V																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																V	V	V		V	V	V																																		
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																								
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V																																				
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																										
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V																																				
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																								
T	2007	Envoy	Chassis	Electronic Brake Control Module																																																								
T	2007	Envoy	Body	Body Control Module																																					V	V	V																	
T	2007	Envoy	Body	Digital Radio Receiver																																																							
T	2007	Envoy	Body	Disc Player and Video Display																																																							
T	2007	Envoy	Body	Driver Door Module																																					V	V	V																	
T	2007	Envoy	Body	Driver Seat Module																																																							
T	2007	Envoy	Body	Generator Battery Control Module																																																							
T	2007	Envoy	Body	HVAC Control Module Auto																																																							
T	2007	Envoy	Body	HVAC Control Module Manual																																																							
T	2007	Envoy	Body	Instrument Panel Cluster																																																							
T	2007	Envoy	Body	Lift Gate Module																																					V																			
T	2007	Envoy	Body	Passenger Door Module																																					V	V	V																	
T	2007	Envoy	Body	Passenger Presence System																																																							
T	2007	Envoy	Body	Uplevel Radio																																																							
T	2007	Envoy	Body	Navigation Radio																																																							
T	2007	Envoy	Body	Rear Seat Audio																																																							
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																					V																			V
T	2007	Envoy	Body	Theft Deterrent Module																																					V																			
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																																							
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																										
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V																																				
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																										
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V																																				
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2008	Canyon	Body	Body Control Module																																					V	V	V																
T	2008	Canyon	Body	Digital Radio Receiver																																																						
T	2008	Canyon	Body	Generator Battery Control Module																																																						
T	2008	Canyon	Body	Instrument Panel Cluster																																					V	V																	
T	2008	Canyon	Body	Passenger Presence System																																																						
T	2008	Canyon	Body	Base Radio																																																						
T	2008	Canyon	Body	Uplevel Radio																																																						
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																					V																		V
T	2008	Canyon	Body	Theft Deterrent Module																																					V																		
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																																						
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																										V	V	V	V																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V																																			
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																							
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																										V		V	V																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V																																			
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																							
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																										V		V	V																										
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V																																			
T	2008	Envoy	Chassis	Electronic Brake Control Module																																																						
T	2008	Envoy	Body	Body Control Module																																					V	V	V																
T	2008	Envoy	Body	Digital Radio Receiver																																																						
T	2008	Envoy	Body	Disc Player and Video Display																																																						
T	2008	Envoy	Body	Driver Door Module																																					V	V	V																
T	2008	Envoy	Body	Driver Seat Module																																																						
T	2008	Envoy	Body	Generator Battery Control Module																																																						
T	2008	Envoy	Body	HVAC Control Module Auto																																																						
T	2008	Envoy	Body	HVAC Control Module Manual																																																						
T	2008	Envoy	Body	Instrument Panel Cluster																																																						
T	2008	Envoy	Body	Lift Gate Module																																					V																		
T	2008	Envoy	Body	Passenger Door Module																																					V	V	V																
T	2008	Envoy	Body	Passenger Presence System																																																						
T	2008	Envoy	Body	Uplevel Radio																																																						
T	2008	Envoy	Body	Navigation Radio																																																						
T	2008	Envoy	Body	Rear Seat Audio																																																						
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																					V																		V
T	2008	Envoy	Body	Theft Deterrent Module																																					V																		
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																																						
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																										V	V	V	V																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V										V																							
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																						
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																						
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																										V	V	V	V																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V										V																							
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																						
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																						
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																										V		V	V																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																V	V	V		V	V	V										V																							
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																						
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																						
T	2009	Canyon	Chassis	Electronic Brake Control Module																																			V																			
T	2009	Canyon	Body	Body Control Module																																					V	V	V																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2009	Canyon	Body	Digital Radio Receiver																																																								
T	2009	Canyon	Body	Generator Battery Control Module																																																								
T	2009	Canyon	Body	Instrument Panel Cluster																																					V	V																		
T	2009	Canyon	Body	Passenger Presence System																																																							
T	2009	Canyon	Body	Base Radio																																																							
T	2009	Canyon	Body	Uplevel Radio																																																							
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																					V																			V
T	2009	Canyon	Body	Theft Deterrent Module																																					V																			
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																											V	V	V	V																										
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																V	V	V		V	V	V											V																							
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																								
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																											V		V	V																										
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																V	V	V		V	V	V											V																							
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																											V		V	V																										
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																V	V	V		V	V	V											V																							
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																								
T	2009	Envoy	Body	Body Control Module																																					V	V	V																	
T	2009	Envoy	Body	Digital Radio Receiver																																																								
T	2009	Envoy	Body	Disc Player and Video Display																																																								
T	2009	Envoy	Body	Driver Door Module																																					V	V	V																	
T	2009	Envoy	Body	Driver Seat Module																																																								
T	2009	Envoy	Body	Generator Battery Control Module																																																								
T	2009	Envoy	Body	HVAC Control Module Auto																																																								
T	2009	Envoy	Body	HVAC Control Module Manual																																																								
T	2009	Envoy	Body	Instrument Panel Cluster																																																								
T	2009	Envoy	Body	Lift Gate Module																																					V																			
T	2009	Envoy	Body	Passenger Door Module																																					V	V	V																	
T	2009	Envoy	Body	Passenger Presence System																																																								
T	2009	Envoy	Body	Uplevel Radio																																																								
T	2009	Envoy	Body	Navigation Radio																																																								
T	2009	Envoy	Body	Rear Seat Audio																																																								
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																					V																			V
T	2009	Envoy	Body	Theft Deterrent Module																																					V																			
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V											V																							
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																							
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																											V		V	V																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																V	V	V		V	V	V											V																							
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																								
T	2010	ALL	Chassis	Electronic Brake Control Module																																			V																					
T	2010	ALL	Body	Body Control Module																																					V	V	V																	
T	2010	ALL	Body	Digital Radio Receiver																																																								
T	2010	ALL	Body	Generator Battery Control Module																																																								
T	2010	ALL	Body	Instrument Panel Cluster																																					V	V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
T	2010	ALL	Body	Passenger Presence System																																																								
T	2010	ALL	Body	Personal Audio Link Module																																																								
T	2010	ALL	Body	Base Radio																																																								
T	2010	ALL	Body	Uplevel Radio																																																								
T	2010	ALL	Body	Supplemental Inflatable Restraint																																					V																				V
T	2010	ALL	Body	Theft Deterrent Module																																					V																			
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																								
V	2007	ALL	Powertrain	Engine Control Module																											V		V	V																										
V	2007	ALL	Powertrain	Rear Drive System																																																								
V	2007	ALL	Powertrain	Transmission Control Module																																V																									
V	2007	ALL	Chassis	Electronic Brake Control Module																																			V																					
V	2007	ALL	Body	Body Control Module			V																																			V	V																	
V	2007	ALL	Body	Digital Radio Receiver																																																								
V	2007	ALL	Body	Driver Door Switch																																					V	V	V																	
V	2007	ALL	Body	Head Up Display																																																								
V	2007	ALL	Body	Heated Seat Module																																																								
V	2007	ALL	Body	HVAC Control Module Auto																																						V		V																	
V	2007	ALL	Body	HVAC Control Module Manual																																						V		V																	
V	2007	ALL	Body	Instrument Panel Cluster																																																								
V	2007	ALL	Body	Lift Gate Module																																					V																			
V	2007	ALL	Body	Park Assist Module																																																								
V	2007	ALL	Body	Passenger Door Switch																																					V	V	V																	
V	2007	ALL	Body	Passenger Presence System																																					V																			
V	2007	ALL	Body	Radio																																																								
V	2007	ALL	Body	Rear HVAC/RSA																																																								
V	2007	ALL	Body	Rollover Sensor																																																								
V	2007	ALL	Body	Supplemental Inflatable Restraint																																					V																			
V	2007	ALL	Body	Theft Deterrent Module																																																								
V	2008	ALL	Powertrain	Engine Control Module																											V		V	V																										
V	2008	ALL	Powertrain	Rear Drive System																																																								
V	2008	ALL	Powertrain	Transmission Control Module																																V																									
V	2008	ALL	Chassis	Electronic Brake Control Module																																			V																					
V	2008	ALL	Body	Body Control Module			V																																			V	V																	
V	2008	ALL	Body	Digital Radio Receiver																																																								
V	2008	ALL	Body	Driver Door Switch																																					V	V	V																	
V	2008	ALL	Body	Head Up Display																																																								
V	2008	ALL	Body	Heated Seat Module																																																								
V	2008	ALL	Body	HVAC Control Module Auto																																						V		V																	
V	2008	ALL	Body	HVAC Control Module Manual																																						V		V																	
V	2008	ALL	Body	Instrument Panel Cluster																																																								
V	2008	ALL	Body	Lift Gate Module																																					V																			
V	2008	ALL	Body	Park Assist Module																																																								
V	2008	ALL	Body	Passenger Door Switch																																					V	V	V																	
V	2008	ALL	Body	Passenger Presence System																																					V																			
V	2008	ALL	Body	Radio																																																								
V	2008	ALL	Body	Rear HVAC/RSA																																																								
V	2008	ALL	Body	Rollover Sensor																																																								
V	2008	ALL	Body	Supplemental Inflatable Restraint																																					V																			
V	2008	ALL	Body	Theft Deterrent Module																																																								
V	2009	ALL	Powertrain	Engine Control Module																											V		V	V																										
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
V	2009	ALL	Powertrain	Rear Drive System																																																								
V	2009	ALL	Powertrain	Transmission Control Module																																V																								
V	2009	ALL	Chassis	Electronic Brake Control Module																																			V																					
V	2009	ALL	Body	Body Control Module			V																																			V	V																	
V	2009	ALL	Body	Digital Radio Receiver																																																							
V	2009	ALL	Body	Driver Door Switch																																					V	V	V																	
V	2009	ALL	Body	Head Up Display																																																							
V	2009	ALL	Body	Heated Seat Module																																																							
V	2009	ALL	Body	HVAC Control Module Auto																																						V		V																
V	2009	ALL	Body	HVAC Control Module Manual																																						V		V																
V	2009	ALL	Body	Instrument Panel Cluster																																																							
V	2009	ALL	Body	Lift Gate Module																																					V																			
V	2009	ALL	Body	Park Assist Module																																																							
V	2009	ALL	Body	Passenger Door Switch																																					V	V	V																	
V	2009	ALL	Body	Passenger Presence System																																					V																			
V	2009	ALL	Body	Radio																																																							
V	2009	ALL	Body	Rear HVAC/RSA																																																							
V	2009	ALL	Body	Rollover Sensor																																																							
V	2009	ALL	Body	Supplemental Inflatable Restraint																																					V																			
V	2009	ALL	Body	Theft Deterrent Module																																																							
V	2010	ALL	Powertrain	Engine Control Module																											V	V	V	V																											
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																							
V	2010	ALL	Powertrain	Rear Drive System																																																							
V	2010	ALL	Powertrain	Transmission Control Module																																V	V																							
V	2010	ALL	Chassis	Electronic Brake Control Module																																			V																					
V	2010	ALL	Body	Body Control Module			V																																			V	V																	
V	2010	ALL	Body	Digital Radio Receiver																																																							
V	2010	ALL	Body	Driver Door Switch																																					V	V	V																	
V	2010	ALL	Body	Head Up Display																																																							
V	2010	ALL	Body	Heated Seat Module																																																							
V	2010	ALL	Body	HVAC Control Module Auto																																						V		V																
V	2010	ALL	Body	HVAC Control Module Manual																																						V		V																
V	2010	ALL	Body	Instrument Panel Cluster																																																							
V	2010	ALL	Body	Lift Gate Module																																					V																			
V	2010	ALL	Body	Park Assist Module																																																							
V	2010	ALL	Body	Passenger Door Switch																																					V	V	V																	
V	2010	ALL	Body	Passenger Presence System																																					V																			
V	2010	ALL	Body	Radio																																																							
V	2010	ALL	Body	Rear HVAC/RSA																																																							
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																							
V	2010	ALL	Body	Theft Deterrent Module																																																							
V	2011	ALL	Powertrain	Engine Control Module																											V	V	V	V																											
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																							
V	2011	ALL	Powertrain	Rear Drive System																																																							
V	2011	ALL	Powertrain	Transmission Control Module																																V	V																							
V	2011	ALL	Chassis	Electronic Brake Control Module																																			V																					
V	2011	ALL	Body	Body Control Module			V																																			V	V																	
V	2011	ALL	Body	Digital Radio Receiver																																																							
V	2011	ALL	Body	Driver Door Switch																																					V	V	V																	
V	2011	ALL	Body	Head Up Display																																																							
V	2011	ALL	Body	Heated Seat Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
V	2011	ALL	Body	HVAC Control Module Auto																																						V		V																
V	2011	ALL	Body	HVAC Control Module Manual																																						V		V																
V	2011	ALL	Body	Instrument Panel Cluster																																																								
V	2011	ALL	Body	Lift Gate Module																																				V																				
V	2011	ALL	Body	Park Assist Module																																																								
V	2011	ALL	Body	Passenger Door Switch																																				V	V	V																		
V	2011	ALL	Body	Passenger Presence System																																				V																				
V	2011	ALL	Body	Radio																																																								
V	2011	ALL	Body	Rear HVAC/RSA																																																								
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2011	ALL	Body	Theft Deterrent Module																																																								
V	2012	ALL	Powertrain	Engine Control Module																											V	V	V	V																											
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2012	ALL	Powertrain	Rear Drive System																																																								
V	2012	ALL	Powertrain	Transmission Control Module																																V	V																							
V	2012	ALL	Chassis	Electronic Brake Control Module																																			V																				
V	2012	ALL	Body	Body Control Module			V																																			V	V																	
V	2012	ALL	Body	Digital Radio Receiver																																																								
V	2012	ALL	Body	Driver Door Switch																																				V	V	V																		
V	2012	ALL	Body	Head Up Display																																																								
V	2012	ALL	Body	Heated Seat Module																																																								
V	2012	ALL	Body	HVAC Control Module Auto																																						V		V																	
V	2012	ALL	Body	HVAC Control Module Manual																																						V		V																	
V	2012	ALL	Body	Instrument Panel Cluster																																																								
V	2012	ALL	Body	Lift Gate Module																																				V																				
V	2012	ALL	Body	Park Assist Module																																																								
V	2012	ALL	Body	Passenger Door Switch																																				V	V	V																		
V	2012	ALL	Body	Passenger Presence System																																				V																				
V	2012	ALL	Body	Radio																																																								
V	2012	ALL	Body	Rear HVAC/RSA																																																								
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2012	ALL	Body	Theft Deterrent Module																																																								
V	2013	ALL	Powertrain	Engine Control Module																											V	V	V	V																											
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2013	ALL	Powertrain	Rear Drive System																																																								
V	2013	ALL	Powertrain	Transmission Control Module																																V	V																							
V	2013	ALL	Chassis	Electronic Brake Control Module																																			V																				
V	2013	ALL	Body	Body Control Module			V																																			V	V																	
V	2013	ALL	Body	Digital Radio Receiver																																																								
V	2013	ALL	Body	Driver Door Switch																																				V	V	V																		
V	2013	ALL	Body	Head Up Display																																																								
V	2013	ALL	Body	Heated Seat Module																																																								
V	2013	ALL	Body	HVAC Control Module Auto																																						V		V																	
V	2013	ALL	Body	HVAC Control Module Manual																																						V		V																	
V	2013	ALL	Body	Instrument Panel Cluster																																																								
V	2013	ALL	Body	Left Side Object Detection Module																																																								
V	2013	ALL	Body	Lift Gate Module																																				V																				
V	2013	ALL	Body	Park Assist Module																																																								
V	2013	ALL	Body	Passenger Door Switch																																				V	V	V																		
V	2013	ALL	Body	Passenger Presence System																																				V																				
V	2013	ALL	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
V	2013	ALL	Body	Rear HVAC/RSA																																																									
V	2013	ALL	Body	Right Side Object Detection Module																																																									
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2013	ALL	Body	Theft Deterrent Module																																																									
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2014	Acadia	Powertrain	Chassis Control Module																																																									
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																									
V	2014	Acadia	Chassis	Electronic Brake Control Module																																																									
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																									
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2014	Acadia	Body	Passenger Presence Module																																																									
V	2014	Acadia	Body	Instrument Cluster																																																									
V	2014	Acadia	Body	Head-Up Display Module																																																									
V	2014	Acadia	Body	Radio																																																									
V	2014	Acadia	Body	Rear Audio Control Module																																																									
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																									
V	2014	Acadia	Body	Personal Audio Link Control Module																																																									
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																									
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																									
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																									
V	2014	Acadia	Body	Liftgate Control Module																																																									
V	2014	Acadia	Body	Seat Memory Control Module																																																									
V	2014	Acadia	Body	Front Seat Heating Control Module																																																									
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																									
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																									
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																									
V	2014	Acadia	Body	Parking Assist Control Module																																																									
V	2014	Acadia	Body	Frontview Camera Module																																																									
V	2014	Acadia	Body	Theft Deterrent Module																																																									
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																									
V	2015	Acadia	Chassis	Electronic Brake Control Module																																																									
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																									
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2015	Acadia	Body	Passenger Presence Module																																																									
V	2015	Acadia	Body	Instrument Cluster																																																									
V	2015	Acadia	Body	Head-Up Display Module																																																									
V	2015	Acadia	Body	Radio																																																									
V	2015	Acadia	Body	Rear Audio Control Module																																																									
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																									
V	2015	Acadia	Body	Personal Audio Link Control Module																																																									
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																									
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																										
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
V	2015	Acadia	Body	Liftgate Control Module																																																										
V	2015	Acadia	Body	Seat Memory Control Module																																																										
V	2015	Acadia	Body	Front Seat Heating Control Module																																																										
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																										
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																										
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																										
V	2015	Acadia	Body	Parking Assist Control Module																																																										
V	2015	Acadia	Body	Frontview Camera Module																																																										
V	2015	Acadia	Body	Theft Deterrent Module																																																										
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Acadia	Chassis	Electronic Brake Control Module																																																										
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Acadia	Body	Passenger Presence Module																																																										
V	2016	Acadia	Body	Instrument Cluster																																																										
V	2016	Acadia	Body	Head-Up Display Module																																																										
V	2016	Acadia	Body	Radio																																																										
V	2016	Acadia	Body	Rear Audio Control Module																																																										
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																										
V	2016	Acadia	Body	Personal Audio Link Control Module																																																										
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																										
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Acadia	Body	Liftgate Control Module																																																										
V	2016	Acadia	Body	Seat Memory Control Module																																																										
V	2016	Acadia	Body	Front Seat Heating Control Module																																																										
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																										
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																										
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																										
V	2016	Acadia	Body	Parking Assist Control Module																																																										
V	2016	Acadia	Body	Frontview Camera Module																																																										
V	2016	Acadia	Body	Theft Deterrent Module																																																										
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																												
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																												
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																								
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																												
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																								
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																											
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																							
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																											
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																V	V																							
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																											
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																				V	V	V	V	V																																	
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																											V			V																											
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																				V	V	V	V	V																																	
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																			V																					
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																								
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
1	2011	Sierra	Chassis	Electronic Suspension Control																																																								
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																								
1	2011	Sierra	Body	Amplifier (Bose)																																																								
1	2011	Sierra	Body	Body Control Module			V																																			V	V																	
1	2011	Sierra	Body	Body Control Module (aux.)																																																								
1	2011	Sierra	Body	Digital Radio Receiver																																																								
1	2011	Sierra	Body	Driver Door Switch																																					V	V	V																	
1	2011	Sierra	Body	HVAC Control Module Auto																																						V		V																
1	2011	Sierra	Body	HVAC Control Module Manual																																						V		V																
1	2011	Sierra	Body	Instrument Panel Cluster																																																								
1	2011	Sierra	Body	Memory Seat Module																																																								
1	2011	Sierra	Body	Park Assist Module																																																								
1	2011	Sierra	Body	Passenger Door Switch																																					V	V	V																	
1	2011	Sierra	Body	Passenger Presence System																																					V																			
1	2011	Sierra	Body	Radio																																																								
1	2011	Sierra	Body	Rear Heated Seat Module																																																								
1	2011	Sierra	Body	Rear HVAC/RSA																																																								
1	2011	Sierra	Body	Supplemental Inflatable Restraint																																																								
1	2011	Sierra	Body	Theft Deterrent Module																																																								
1	2011	Sierra Hybrid	Powertrain	Engine Control Module																											V			V																											
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																								
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																								
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																								
1	2011	Sierra Hybrid	Body	Body Control Module			V																																			V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																									
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2011	Sierra Hybrid	Body	Driver Door Switch																																					V	V	V																			
1	2011	Sierra Hybrid	Body	Heated Seat Module																																																										
1	2011	Sierra Hybrid	Body	HVAC Control Module																																						V		V																			
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2011	Sierra Hybrid	Body	Park Assist Module																																																										
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																					V	V	V																			
1	2011	Sierra Hybrid	Body	Passenger Presence System																																					V																			
1	2011	Sierra Hybrid	Body	Radio																																																									
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																												
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																	V	V																								
1	2011	Yukon	Chassis	Electronic Brake Control Module																																			V																							
1	2011	Yukon	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																										
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon	Body	Amplifier (Bose)																																																										
1	2011	Yukon	Body	Assist Step Controller																																																										
1	2011	Yukon	Body	Body Control Module			V																																			V	V																			
1	2011	Yukon	Body	Body Control Module (aux.)																																																										
1	2011	Yukon	Body	Digital Radio Receiver																																																										
1	2011	Yukon	Body	Driver Door Switch																																					V	V	V																			
1	2011	Yukon	Body	HVAC Control Module Auto																																						V		V																		
1	2011	Yukon	Body	HVAC Control Module Manual																																						V		V																		
1	2011	Yukon	Body	Instrument Panel Cluster																																																										
1	2011	Yukon	Body	Left Side Object Detection Module																																																										
1	2011	Yukon	Body	Lift Gate Module																																					V																					
1	2011	Yukon	Body	Memory Seat Module																																																										
1	2011	Yukon	Body	Park Assist Module																																																										
1	2011	Yukon	Body	Passenger Door Switch																																					V	V	V																			
1	2011	Yukon	Body	Passenger Presence System																																					V																					
1	2011	Yukon	Body	Radio																																																										
1	2011	Yukon	Body	Rear Heated Seat Module																																																										
1	2011	Yukon	Body	Rear HVAC/RSA																																																										
1	2011	Yukon	Body	Right Side Object Detection Module																																																										
1	2011	Yukon	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon	Body	Theft Deterrent Module																																																										
1	2011	Yukon Hybrid	Powertrain	Engine Control Module																											V			V																												
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																									
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																									
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																									
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																									
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																									
1	2011	Yukon Hybrid	Body	Body Control Module			V																																			V	V																		
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																									
1	2011	Yukon Hybrid	Body	Driver Door Switch																																					V	V	V																		
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																									
1	2011	Yukon Hybrid	Body	HVAC Control Module																																						V		V																	
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																									
1	2011	Yukon Hybrid	Body	Lift Gate Module																																					V																				
1	2011	Yukon Hybrid	Body	Park Assist Module																																																									
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																					V	V	V																		
1	2011	Yukon Hybrid	Body	Passenger Presence System																																					V																				
1	2011	Yukon Hybrid	Body	Radio																																																									
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																									
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																											
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																							
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																							
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																											
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																							
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																											
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																	V	V																							
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																			V																					
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																									
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																									
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
1	2011	Yukon XL	Body	Amplifier (Bose)																																																									
1	2011	Yukon XL	Body	Assist Step Controller																																																									
1	2011	Yukon XL	Body	Body Control Module			V																																			V	V																		
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																									
1	2011	Yukon XL	Body	Digital Radio Receiver																																																									
1	2011	Yukon XL	Body	Driver Door Switch																																					V	V	V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2011	Yukon XL	Body	HVAC Control Module Auto																																						V		V																
1	2011	Yukon XL	Body	HVAC Control Module Manual																																						V		V																
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																								
1	2011	Yukon XL	Body	Left Side Object Detection Module																																																								
1	2011	Yukon XL	Body	Lift Gate Module																																					V																				
1	2011	Yukon XL	Body	Memory Seat Module																																																								
1	2011	Yukon XL	Body	Park Assist Module																																																								
1	2011	Yukon XL	Body	Passenger Door Switch																																					V	V	V																		
1	2011	Yukon XL	Body	Passenger Presence System																																					V																				
1	2011	Yukon XL	Body	Radio																																																								
1	2011	Yukon XL	Body	Rear Heated Seat Module																																																								
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																								
1	2011	Yukon XL	Body	Right Side Object Detection Module																																																								
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
1	2011	Yukon XL	Body	Theft Deterrent Module																																																								
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V										V																								
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V										V																								
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																										
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																V	V																								
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																								
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																								
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																V	V																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																				V	V	V	V	V																																
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																											V			V																										
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																				V	V	V	V	V																																
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																			V																					
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																								
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
1	2012	Sierra	Chassis	Electronic Suspension Control																																																								
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																								
1	2012	Sierra	Body	Amplifier (Bose)																																																								
1	2012	Sierra	Body	Body Control Module			V																																			V	V																	
1	2012	Sierra	Body	Body Control Module (aux.)																																																								
1	2012	Sierra	Body	Digital Radio Receiver																																																								
1	2012	Sierra	Body	Driver Door Switch																																					V	V	V																		
1	2012	Sierra	Body	HVAC Control Module Auto																																						V		V																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2012	Sierra	Body	HVAC Control Module Manual																																						V		V																
1	2012	Sierra	Body	Instrument Panel Cluster																																																							
1	2012	Sierra	Body	Memory Seat Module																																																							
1	2012	Sierra	Body	Park Assist Module																																																							
1	2012	Sierra	Body	Passenger Door Switch																																					V	V	V																	
1	2012	Sierra	Body	Passenger Presence System																																					V																			
1	2012	Sierra	Body	Radio																																																							
1	2012	Sierra	Body	Navigation Radio																																																							
1	2012	Sierra	Body	Rear Heated Seat Module																																																							
1	2012	Sierra	Body	Rear HVAC/RSA																																																							
1	2012	Sierra	Body	Supplemental Inflatable Restraint																																																							
1	2012	Sierra	Body	Theft Deterrent Module																																																							
1	2012	Sierra Hybrid	Powertrain	Engine Control Module																											V		V																												
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																							
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																							
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																							
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																							
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																							
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																							
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																							
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																							
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																							
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																							
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																							
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																							
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																							
1	2012	Sierra Hybrid	Body	Body Control Module			V																																			V	V																	
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																							
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																							
1	2012	Sierra Hybrid	Body	Driver Door Switch																																					V	V	V																	
1	2012	Sierra Hybrid	Body	Heated Seat Module																																																							
1	2012	Sierra Hybrid	Body	HVAC Control Module																																						V		V																	
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																							
1	2012	Sierra Hybrid	Body	Park Assist Module																																																							
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																					V	V	V																	
1	2012	Sierra Hybrid	Body	Passenger Presence System																																					V																			
1	2012	Sierra Hybrid	Body	Radio																																																							
1	2012	Sierra Hybrid	Body	Navigation Radio																																																							
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																							
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																							
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																							
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																							
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																							
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																						
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																							
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																V	V																						
1	2012	Yukon	Chassis	Electronic Brake Control Module																																			V																					
1	2012	Yukon	Chassis	Electronic Suspension Control																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																								
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
1	2012	Yukon	Body	Amplifier (Bose)																																																								
1	2012	Yukon	Body	Assist Step Controller																																																								
1	2012	Yukon	Body	Body Control Module			V																																			V	V																	
1	2012	Yukon	Body	Body Control Module (aux.)																																																								
1	2012	Yukon	Body	Digital Radio Receiver																																																								
1	2012	Yukon	Body	Driver Door Switch																																					V	V	V																	
1	2012	Yukon	Body	HVAC Control Module Auto																																						V		V																
1	2012	Yukon	Body	HVAC Control Module Manual																																						V		V																
1	2012	Yukon	Body	Instrument Panel Cluster																																																								
1	2012	Yukon	Body	Left Side Object Detection Module																																																								
1	2012	Yukon	Body	Lift Gate Module																																					V																				
1	2012	Yukon	Body	Memory Seat Module																																																								
1	2012	Yukon	Body	Park Assist Module																																																								
1	2012	Yukon	Body	Passenger Door Switch																																					V	V	V																	
1	2012	Yukon	Body	Passenger Presence System																																					V																			
1	2012	Yukon	Body	Radio																																																								
1	2012	Yukon	Body	Navigation Radio																																																								
1	2012	Yukon	Body	Rear Heated Seat Module																																																								
1	2012	Yukon	Body	Rear HVAC/RSA																																																								
1	2012	Yukon	Body	Right Side Object Detection Module																																																								
1	2012	Yukon	Body	Supplemental Inflatable Restraint																																																								
1	2012	Yukon	Body	Theft Deterrent Module																																																								
1	2012	Yukon Hybrid	Powertrain	Engine Control Module																											V		V																											
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																								
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																								
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																								
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																								
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																								
1	2012	Yukon Hybrid	Body	Body Control Module			V																																			V	V																	
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																								
1	2012	Yukon Hybrid	Body	Driver Door Switch																																					V	V	V																	
1	2012	Yukon Hybrid	Body	Heated Seat Module																																																								
1	2012	Yukon Hybrid	Body	HVAC Control Module																																						V		V																
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
1	2012	Yukon Hybrid	Body	Lift Gate Module																																					V																			
1	2012	Yukon Hybrid	Body	Park Assist Module																																																								
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																					V	V	V																	
1	2012	Yukon Hybrid	Body	Passenger Presence System																																					V																			

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2012	Yukon Hybrid	Body	Radio																																																								
1	2012	Yukon Hybrid	Body	Navigation Radio																																																								
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																								
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																								
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																										
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																						
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																										
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																	V	V																						
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																				V																				
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																								
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																								
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																								
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
1	2012	Yukon XL	Body	Amplifier (Bose)																																																								
1	2012	Yukon XL	Body	Assist Step Controller																																																								
1	2012	Yukon XL	Body	Body Control Module			V																																				V	V																
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																								
1	2012	Yukon XL	Body	Digital Radio Receiver																																																								
1	2012	Yukon XL	Body	Driver Door Switch																																					V	V	V																	
1	2012	Yukon XL	Body	HVAC Control Module Auto																																							V		V															
1	2012	Yukon XL	Body	HVAC Control Module Manual																																							V		V															
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																								
1	2012	Yukon XL	Body	Left Side Object Detection Module																																																								
1	2012	Yukon XL	Body	Lift Gate Module																																					V																			
1	2012	Yukon XL	Body	Memory Seat Module																																																								
1	2012	Yukon XL	Body	Park Assist Module																																																								
1	2012	Yukon XL	Body	Passenger Door Switch																																					V	V	V																	
1	2012	Yukon XL	Body	Passenger Presence System																																					V																			
1	2012	Yukon XL	Body	Radio																																																								
1	2012	Yukon XL	Body	Navigation Radio																																																								
1	2012	Yukon XL	Body	Rear Heated Seat Module																																																								
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																								
1	2012	Yukon XL	Body	Right Side Object Detection Module																																																								
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
1	2012	Yukon XL	Body	Theft Deterrent Module																																																								
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																											
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																								
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																								
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																											
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																								
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																											
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																									
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																	V	V																								
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																											
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																								
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																											V			V																											
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																									
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																									
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																				V	V	V	V	V																																	
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																			V																						
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																									
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																									
1	2013	Sierra	Chassis	Electronic Suspension Control																																																									
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Sierra	Body	Amplifier (Bose)																																																									
1	2013	Sierra	Body	Body Control Module			V																																			V	V																		
1	2013	Sierra	Body	Body Control Module (aux.)																																																									
1	2013	Sierra	Body	Digital Radio Receiver																																																									
1	2013	Sierra	Body	Driver Door Switch																																					V	V	V																		
1	2013	Sierra	Body	HVAC Control Module Auto																																						V		V																	
1	2013	Sierra	Body	HVAC Control Module Manual																																						V		V																	
1	2013	Sierra	Body	Instrument Panel Cluster																																																									
1	2013	Sierra	Body	Memory Seat Module																																																									
1	2013	Sierra	Body	Park Assist Module																																																									
1	2013	Sierra	Body	Passenger Door Switch																																					V	V	V																		
1	2013	Sierra	Body	Passenger Presence System																																					V																				
1	2013	Sierra	Body	Radio																																																									
1	2013	Sierra	Body	Navigation Radio																																																									
1	2013	Sierra	Body	Rear Heated Seat Module																																																									
1	2013	Sierra	Body	Rear HVAC/RSA																																																									
1	2013	Sierra	Body	Supplemental Inflatable Restraint																																																									
1	2013	Sierra	Body	Theft Deterrent Module																																																									
1	2013	Sierra Hybrid	Powertrain	Engine Control Module																											V			V																											
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																									
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																									
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																									
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																									
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																									
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																								
1	2013	Sierra Hybrid	Body	Body Control Module			V																																			V	V																	
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																								
1	2013	Sierra Hybrid	Body	Driver Door Switch																																					V	V	V																	
1	2013	Sierra Hybrid	Body	Heated Seat Module																																																								
1	2013	Sierra Hybrid	Body	HVAC Control Module																																						V		V																
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
1	2013	Sierra Hybrid	Body	Park Assist Module																																																								
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																					V	V	V																	
1	2013	Sierra Hybrid	Body	Passenger Presence System																																					V																			
1	2013	Sierra Hybrid	Body	Radio																																																								
1	2013	Sierra Hybrid	Body	Navigation Radio																																																								
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																								
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																										
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																V	V																							
1	2013	Yukon	Chassis	Electronic Brake Control Module																																			V																					
1	2013	Yukon	Chassis	Electronic Suspension Control																																																								
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Yukon	Body	Amplifier (Bose)																																																								
1	2013	Yukon	Body	Assist Step Controller																																																								
1	2013	Yukon	Body	Body Control Module			V																																			V	V																	
1	2013	Yukon	Body	Body Control Module (aux.)																																																								
1	2013	Yukon	Body	Digital Radio Receiver																																																								
1	2013	Yukon	Body	Driver Door Switch																																					V	V	V																	
1	2013	Yukon	Body	HVAC Control Module Auto																																						V		V																
1	2013	Yukon	Body	HVAC Control Module Manual																																						V		V																
1	2013	Yukon	Body	Instrument Panel Cluster																																																								
1	2013	Yukon	Body	Left Side Object Detection Module																																																								
1	2013	Yukon	Body	Lift Gate Module																																					V																			
1	2013	Yukon	Body	Memory Seat Module																																																								
1	2013	Yukon	Body	Park Assist Module																																																								
1	2013	Yukon	Body	Passenger Door Switch																																					V	V	V																	
1	2013	Yukon	Body	Passenger Presence System																																					V																			
1	2013	Yukon	Body	Radio																																																								
1	2013	Yukon	Body	Navigation Radio																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2013	Yukon	Body	Rear Heated Seat Module																																																								
1	2013	Yukon	Body	Rear HVAC/RSA																																																								
1	2013	Yukon	Body	Right Side Object Detection Module																																																								
1	2013	Yukon	Body	Supplemental Inflatable Restraint																																																								
1	2013	Yukon	Body	Theft Deterrent Module																																																								
1	2013	Yukon Hybrid	Powertrain	Engine Control Module																											V			V																										
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																								
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																								
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																								
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																								
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																								
1	2013	Yukon Hybrid	Body	Body Control Module			V																																			V	V																	
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																								
1	2013	Yukon Hybrid	Body	Driver Door Switch																																					V	V	V																	
1	2013	Yukon Hybrid	Body	Heated Seat Module																																																								
1	2013	Yukon Hybrid	Body	HVAC Control Module																																						V		V																
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
1	2013	Yukon Hybrid	Body	Lift Gate Module																																					V																			
1	2013	Yukon Hybrid	Body	Park Assist Module																																																								
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																					V	V	V																	
1	2013	Yukon Hybrid	Body	Passenger Presence System																																					V																			
1	2013	Yukon Hybrid	Body	Radio																																																								
1	2013	Yukon Hybrid	Body	Navigation Radio																																																								
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																								
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																								
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																										
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																						
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																										
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																	V	V																						
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																				V																			
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																							
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																							
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																							
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																							
1	2013	Yukon XL	Body	Amplifier (Bose)																																																							
1	2013	Yukon XL	Body	Assist Step Controller																																																							
1	2013	Yukon XL	Body	Body Control Module			V																																			V	V																	
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																							
1	2013	Yukon XL	Body	Digital Radio Receiver																																																							
1	2013	Yukon XL	Body	Driver Door Switch																																					V	V	V																	
1	2013	Yukon XL	Body	HVAC Control Module Auto																																						V		V																
1	2013	Yukon XL	Body	HVAC Control Module Manual																																						V		V																
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																							
1	2013	Yukon XL	Body	Left Side Object Detection Module																																																							
1	2013	Yukon XL	Body	Lift Gate Module																																					V																			
1	2013	Yukon XL	Body	Memory Seat Module																																																							
1	2013	Yukon XL	Body	Park Assist Module																																																							
1	2013	Yukon XL	Body	Passenger Door Switch																																					V	V	V																	
1	2013	Yukon XL	Body	Passenger Presence System																																					V																			
1	2013	Yukon XL	Body	Radio																																																							
1	2013	Yukon XL	Body	Navigation Radio																																																							
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																							
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																							
1	2013	Yukon XL	Body	Right Side Object Detection Module																																																							
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																							
1	2013	Yukon XL	Body	Theft Deterrent Module																																																							
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																							
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																							
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																							
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																							
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																							
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																							
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																							
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																							
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																							
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																							
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																							
1	2014	Sierra	Chassis	Electronic Brake Control Module																																																							
1	2014	Sierra	Chassis	Parking Brake Control Module																																																							
1	2014	Sierra	Chassis	Power Steering Control Module																																																							
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																							
1	2014	Sierra	Body	Body Control Module																																																							
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
1	2014	Sierra	Body	Passenger Presence Module																																																							
1	2014	Sierra	Body	Instrument Cluster																																																							
1	2014	Sierra	Body	Radio Control																																																							
1	2014	Sierra	Body	HVAC Control																																																							
1	2014	Sierra	Body	Radio																																																							
1	2014	Sierra	Body	Amplifier																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2014	Sierra	Body	Media Disc Player																																																									
1	2014	Sierra	Body	Human Machine Interface Control Module																																																										
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2014	Sierra	Body	Parking Assist Control Module																																																										
1	2014	Sierra	Body	Frontview Camera Module																																																										
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																										
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Suspension Control Module																																																										
1	2014	Sierra HD	Body	Body Control Module																																																										
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Sierra HD	Body	Instrument Cluster																																																										
1	2014	Sierra HD	Body	Base Radio																																																										
1	2014	Sierra HD	Body	Navigation Radio																																																										
1	2014	Sierra HD	Body	Uplevel Radio																																																										
1	2014	Sierra HD	Body	Amplifier																																																										
1	2014	Sierra HD	Body	Rear Audio Control Module																																																										
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																										
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																										
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Sierra HD	Body	Seat Memory Control Module																																																										
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																										
1	2014	Sierra HD	Body	Parking Assist Control Module																																																										
1	2014	Sierra HD	Body	Theft Deterrent Module																																																										
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																										
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2014	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2014	Yukon	Chassis	Parking Brake Control Module																																																										
1	2014	Yukon	Chassis	Suspension Control Module																																																										
1	2014	Yukon	Body	Body Control Module																																																										
1	2014	Yukon	Body	Auxiliary Body Control Module																																																										
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Yukon	Body	Passenger Presence Module																																																										
1	2014	Yukon	Body	Instrument Cluster																																																										
1	2014	Yukon	Body	Base Radio																																																										
1	2014	Yukon	Body	Navigation Radio																																																										
1	2014	Yukon	Body	Uplevel Radio																																																										
1	2014	Yukon	Body	Amplifier																																																										
1	2014	Yukon	Body	Rear Audio Control Module																																																										
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																																										
1	2014	Yukon	Body	Personal Audio Link Control Module																																																										
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Yukon	Body	Liftgate Control Module																																																										
1	2014	Yukon	Body	Seat Memory Control Module																																																										
1	2014	Yukon	Body	Rear Seat Heating Control Module																																																										
1	2014	Yukon	Body	Assist Step Control Module																																																										
1	2014	Yukon	Body	Right Side Object Detection Control Module																																																										
1	2014	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																																										
1	2014	Yukon	Body	Parking Assist Control Module																																																										
1	2014	Yukon	Body	Theft Deterrent Module																																																										
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																										
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2014	Yukon XL	Chassis	Suspension Control Module																																																										
1	2014	Yukon XL	Body	Body Control Module																																																										
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																																										
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Yukon XL	Body	Passenger Presence Module																																																										
1	2014	Yukon XL	Body	Instrument Cluster																																																										
1	2014	Yukon XL	Body	Base Radio																																																										
1	2014	Yukon XL	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2014	Yukon XL	Body	Uplevel Radio																																																								
1	2014	Yukon XL	Body	Amplifier																																																								
1	2014	Yukon XL	Body	Rear Audio Control Module																																																								
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																								
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																																								
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																								
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																								
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																								
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																								
1	2014	Yukon XL	Body	Liftgate Control Module																																																								
1	2014	Yukon XL	Body	Seat Memory Control Module																																																								
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																								
1	2014	Yukon XL	Body	Assist Step Control Module																																																								
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																								
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																								
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																								
1	2014	Yukon XL	Body	Parking Assist Control Module																																																								
1	2014	Yukon XL	Body	Theft Deterrent Module																																																								
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																								
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																								
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																								
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																								
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																								
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																								
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																								
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
1	2015	Sierra	Chassis	Electronic Brake Control Module																																																								
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																								
1	2015	Sierra	Chassis	Power Steering Control Module																																																								
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2015	Sierra	Chassis	Suspension Control Module																																																								
1	2015	Sierra	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2015	Sierra	Body	Passenger Presence Module																																																										
1	2015	Sierra	Body	Instrument Cluster																																																										
1	2015	Sierra	Body	Radio Controls																																																									
1	2015	Sierra	Body	HVAC Controls																																																									
1	2015	Sierra	Body	Radio																																																									
1	2015	Sierra	Body	Amplifier																																																									
1	2015	Sierra	Body	Media Disc Player																																																									
1	2015	Sierra	Body	Human Machine Interface Control Module																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																									
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																									
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																									
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																									
1	2015	Sierra	Body	Parking Assist Control Module																																																									
1	2015	Sierra	Body	Frontview Camera Module																																																									
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																									
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																									
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																									
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																									
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																									
1	2015	Yukon	Chassis	Electronic Brake Control Module																																																									
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																									
1	2015	Yukon	Chassis	Parking Brake Control Module																																																									
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																									
1	2015	Yukon	Chassis	Power Steering Control Module																																																									
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2015	Yukon	Chassis	Suspension Control Module																																																									
1	2015	Yukon	Body	Body Control Module																																																									
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2015	Yukon	Body	Passenger Presence Module																																																									
1	2015	Yukon	Body	Instrument Cluster																																																									
1	2015	Yukon	Body	Radio Controls																																																									
1	2015	Yukon	Body	HVAC Controls																																																									
1	2015	Yukon	Body	Radio																																																									
1	2015	Yukon	Body	Amplifier																																																									
1	2015	Yukon	Body	Media Disc Player																																																									
1	2015	Yukon	Body	Human Machine Interface Control Module																																																									
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																									
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																									
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2015	Yukon	Body	HVAC Control Module																																																									
1	2015	Yukon	Body	Liftgate Control Module																																																										
1	2015	Yukon	Body	Keyless Entry Control Module																																																										
1	2015	Yukon	Body	Assist Step Control Module																																																										
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon	Body	Parking Assist Control Module																																																										
1	2015	Yukon	Body	Frontview Camera Module																																																										
1	2015	Yukon	Body	Steering Column Lock Control Module																																																										
1	2015	Yukon	Body	Battery Energy Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	Yukon XL	Chassis	Power Steering Control Module																																																										
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Yukon XL	Chassis	Suspension Control Module																																																										
1	2015	Yukon XL	Body	Body Control Module																																																										
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Yukon XL	Body	Passenger Presence Module																																																										
1	2015	Yukon XL	Body	Instrument Cluster																																																										
1	2015	Yukon XL	Body	Radio Controls																																																										
1	2015	Yukon XL	Body	HVAC Controls																																																										
1	2015	Yukon XL	Body	Radio																																																										
1	2015	Yukon XL	Body	Amplifier																																																										
1	2015	Yukon XL	Body	Media Disc Player																																																										
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Yukon XL	Body	HVAC Control Module																																																										
1	2015	Yukon XL	Body	Liftgate Control Module																																																										
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
1	2015	Yukon XL	Body	Assist Step Control Module																																																										
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon XL	Body	Parking Assist Control Module																																																										
1	2015	Yukon XL	Body	Frontview Camera Module																																																										
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																									
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																									
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																									
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																									
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																									
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																									
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																									
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2016	Sierra	Chassis	Electronic Brake Control Module																																																									
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																									
1	2016	Sierra	Chassis	Parking Brake Control Module																																																									
1	2016	Sierra	Chassis	Power Steering Control Module																																																									
1	2016	Sierra	Chassis	Power Steering Control Module																																																									
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2016	Sierra	Chassis	Suspension Control Module																																																									
1	2016	Sierra	Body	Body Control Module																																																									
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2016	Sierra	Body	Passenger Presence Module																																																									
1	2016	Sierra	Body	Instrument Cluster																																																									
1	2016	Sierra	Body	Radio Controls																																																									
1	2016	Sierra	Body	HVAC Controls																																																									
1	2016	Sierra	Body	Radio (IO3)																																																									
1	2016	Sierra	Body	Radio (IOB)																																																									
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																									
1	2016	Sierra	Body	Amplifier																																																									
1	2016	Sierra	Body	Media Disc Player																																																									
1	2016	Sierra	Body	Human Machine Interface Control Module																																																									
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																									
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																									
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																									
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																									
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																									
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																									
1	2016	Sierra	Body	Parking Assist Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2016	Sierra	Body	Frontview Camera Module																																																									
1	2016	Sierra	Body	Frontview Camera Module																																																										
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2016	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Yukon	Chassis	Parking Brake Control Module																																																										
1	2016	Yukon	Chassis	Power Steering Control Module																																																										
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Yukon	Chassis	Suspension Control Module																																																										
1	2016	Yukon	Body	Body Control Module																																																										
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Yukon	Body	Passenger Presence Module																																																										
1	2016	Yukon	Body	Instrument Cluster																																																										
1	2016	Yukon	Body	Radio Controls																																																										
1	2016	Yukon	Body	HVAC Controls																																																										
1	2016	Yukon	Body	Radio																																																										
1	2016	Yukon	Body	Amplifier																																																										
1	2016	Yukon	Body	Media Disc Player																																																										
1	2016	Yukon	Body	Human Machine Interface Control Module																																																										
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																										
1	2016	Yukon	Body	HVAC Control Module																																																										
1	2016	Yukon	Body	Liftgate Control Module																																																										
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																										
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																										
1	2016	Yukon	Body	Keyless Entry Control Module																																																										
1	2016	Yukon	Body	Assist Step Control Module																																																										
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2016	Yukon	Body	Parking Assist Control Module																																																										
1	2016	Yukon	Body	Frontview Camera Module																																																										
1	2016	Yukon	Body	Steering Column Lock Control Module																																																										
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2016	Yukon XL	Chassis	Power Steering Control Module																																																										
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Yukon XL	Chassis	Suspension Control Module																																																										
1	2016	Yukon XL	Body	Body Control Module																																																										
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
1	2016	Yukon XL	Body	Passenger Presence Module																																																								
1	2016	Yukon XL	Body	Instrument Cluster																																																								
1	2016	Yukon XL	Body	Radio Controls																																																								
1	2016	Yukon XL	Body	HVAC Controls																																																								
1	2016	Yukon XL	Body	Radio																																																								
1	2016	Yukon XL	Body	Amplifier																																																								
1	2016	Yukon XL	Body	Media Disc Player																																																								
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																								
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																								
1	2016	Yukon XL	Body	HVAC Control Module																																																								
1	2016	Yukon XL	Body	Liftgate Control Module																																																								
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																								
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																								
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																								
1	2016	Yukon XL	Body	Assist Step Control Module																																																								
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																								
1	2016	Yukon XL	Body	Parking Assist Control Module																																																								
1	2016	Yukon XL	Body	Frontview Camera Module																																																								
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																								
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																							
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																	V	V																						
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																				V	V	V	V	V																																
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																											V			V																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																				V	V	V	V	V																																
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																			V																					
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																								
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
2	2011	Sierra	Chassis	Electronic Suspension Control																																																								
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																								
2	2011	Sierra	Body	Amplifier (Bose)																																																								
2	2011	Sierra	Body	Body Control Module			V																																			V	V																	
2	2011	Sierra	Body	Body Control Module (aux.)																																																								
2	2011	Sierra	Body	Digital Radio Receiver																																																								
2	2011	Sierra	Body	Driver Door Switch																																					V	V	V																	
2	2011	Sierra	Body	HVAC Control Module Auto																																						V		V																
2	2011	Sierra	Body	HVAC Control Module Manual																																						V		V																
2	2011	Sierra	Body	Instrument Panel Cluster																																																								
2	2011	Sierra	Body	Memory Seat Module																																																								
2	2011	Sierra	Body	Park Assist Module																																																								
2	2011	Sierra	Body	Passenger Door Switch																																					V	V	V																	
2	2011	Sierra	Body	Passenger Presence System																																					V																			
2	2011	Sierra	Body	Radio																																																								
2	2011	Sierra	Body	Rear Heated Seat Module																																																								
2	2011	Sierra	Body	Rear HVAC/RSA																																																								
2	2011	Sierra	Body	Supplemental Inflatable Restraint																																																								
2	2011	Sierra	Body	Theft Deterrent Module																																																								
2	2011	Sierra Hybrid	Powertrain	Engine Control Module																											V		V																											
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																								
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																								
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																								
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																								
2	2011	Sierra Hybrid	Body	Body Control Module			V																																			V	V																	
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																								
2	2011	Sierra Hybrid	Body	Driver Door Switch																																					V	V	V																	
2	2011	Sierra Hybrid	Body	Heated Seat Module																																																								
2	2011	Sierra Hybrid	Body	HVAC Control Module																																						V		V																
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
2	2011	Sierra Hybrid	Body	Park Assist Module																																																								
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																					V	V	V																	
2	2011	Sierra Hybrid	Body	Passenger Presence System																																					V																			
2	2011	Sierra Hybrid	Body	Radio																																																								
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																												V		V	V																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																								
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																												V		V	V																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																	V	V																						
2	2011	Yukon	Chassis	Electronic Brake Control Module																																			V																					
2	2011	Yukon	Chassis	Electronic Suspension Control																																																								
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																								
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
2	2011	Yukon	Body	Amplifier (Bose)																																																								
2	2011	Yukon	Body	Assist Step Controller																																																								
2	2011	Yukon	Body	Body Control Module			V																																				V	V																
2	2011	Yukon	Body	Body Control Module (aux.)																																																								
2	2011	Yukon	Body	Digital Radio Receiver																																																								
2	2011	Yukon	Body	Driver Door Switch																																					V	V	V																	
2	2011	Yukon	Body	HVAC Control Module Auto																																						V		V																
2	2011	Yukon	Body	HVAC Control Module Manual																																						V		V																
2	2011	Yukon	Body	Instrument Panel Cluster																																																								
2	2011	Yukon	Body	Left Side Object Detection Module																																																								
2	2011	Yukon	Body	Lift Gate Module																																					V																			
2	2011	Yukon	Body	Memory Seat Module																																																								
2	2011	Yukon	Body	Park Assist Module																																																								
2	2011	Yukon	Body	Passenger Door Switch																																					V	V	V																	
2	2011	Yukon	Body	Passenger Presence System																																					V																			
2	2011	Yukon	Body	Radio																																																								
2	2011	Yukon	Body	Rear Heated Seat Module																																																								
2	2011	Yukon	Body	Rear HVAC/RSA																																																								
2	2011	Yukon	Body	Right Side Object Detection Module																																																								
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																																								
2	2011	Yukon	Body	Theft Deterrent Module																																																								
2	2011	Yukon Hybrid	Powertrain	Engine Control Module																												V			V																									
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																								
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																								
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																								
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																								
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																								
2	2011	Yukon Hybrid	Body	Body Control Module			V																																			V	V																	
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																								
2	2011	Yukon Hybrid	Body	Driver Door Switch																																					V	V	V																		
2	2011	Yukon Hybrid	Body	Heated Seat Module																																																								
2	2011	Yukon Hybrid	Body	HVAC Control Module																																						V		V																	
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
2	2011	Yukon Hybrid	Body	Lift Gate Module																																					V																				
2	2011	Yukon Hybrid	Body	Park Assist Module																																																								
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																					V	V	V																		
2	2011	Yukon Hybrid	Body	Passenger Presence System																																					V																			
2	2011	Yukon Hybrid	Body	Radio																																																								
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																								
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																								
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																											V		V	V																											
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																V	V																							
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																								
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																								
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																								
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																								
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																											
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																							
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																											
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																V	V																							
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																			V																				
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																								
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																								
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																								
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
2	2011	Yukon XL	Body	Amplifier (Bose)																																																								
2	2011	Yukon XL	Body	Assist Step Controller																																																								
2	2011	Yukon XL	Body	Body Control Module			V																																			V	V																	
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																								
2	2011	Yukon XL	Body	Digital Radio Receiver																																																								
2	2011	Yukon XL	Body	Driver Door Switch																																					V	V	V																		
2	2011	Yukon XL	Body	HVAC Control Module Auto																																						V		V																
2	2011	Yukon XL	Body	HVAC Control Module Manual																																						V		V																
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																								
2	2011	Yukon XL	Body	Left Side Object Detection Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2011	Yukon XL	Body	Lift Gate Module																																					V																			
2	2011	Yukon XL	Body	Memory Seat Module																																																								
2	2011	Yukon XL	Body	Park Assist Module																																																								
2	2011	Yukon XL	Body	Passenger Door Switch																																					V	V	V																	
2	2011	Yukon XL	Body	Passenger Presence System																																					V																			
2	2011	Yukon XL	Body	Radio																																																								
2	2011	Yukon XL	Body	Rear Heated Seat Module																																																								
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																								
2	2011	Yukon XL	Body	Right Side Object Detection Module																																																								
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
2	2011	Yukon XL	Body	Theft Deterrent Module																																																								
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																							
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																										
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																						
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																										
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																						
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																										
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																						
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																				V	V	V	V	V																																
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																											V			V																										
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																				V	V	V	V	V																																
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																			V																					
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																								
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
2	2012	Sierra	Chassis	Electronic Suspension Control																																																								
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																								
2	2012	Sierra	Body	Amplifier (Bose)																																																								
2	2012	Sierra	Body	Body Control Module			V																																			V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2012	Sierra	Body	Body Control Module (aux.)																																																									
2	2012	Sierra	Body	Digital Radio Receiver																																																										
2	2012	Sierra	Body	Driver Door Switch																																					V	V	V																			
2	2012	Sierra	Body	HVAC Control Module Auto																																						V		V																	
2	2012	Sierra	Body	HVAC Control Module Manual																																						V		V																	
2	2012	Sierra	Body	Instrument Panel Cluster																																																									
2	2012	Sierra	Body	Memory Seat Module																																																									
2	2012	Sierra	Body	Park Assist Module																																																									
2	2012	Sierra	Body	Passenger Door Switch																																					V	V	V																			
2	2012	Sierra	Body	Passenger Presence System																																					V																			
2	2012	Sierra	Body	Radio																																																									
2	2012	Sierra	Body	Navigation Radio																																																									
2	2012	Sierra	Body	Rear Heated Seat Module																																																										
2	2012	Sierra	Body	Rear HVAC/RSA																																																										
2	2012	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra	Body	Theft Deterrent Module																																																										
2	2012	Sierra Hybrid	Powertrain	Engine Control Module																											V		V																													
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Sierra Hybrid	Body	Body Control Module			V																																			V	V																		
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Sierra Hybrid	Body	Driver Door Switch																																					V	V	V																			
2	2012	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	HVAC Control Module																																						V		V																		
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2012	Sierra Hybrid	Body	Park Assist Module																																																										
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																					V	V	V																			
2	2012	Sierra Hybrid	Body	Passenger Presence System																																					V																			
2	2012	Sierra Hybrid	Body	Radio																																																										
2	2012	Sierra Hybrid	Body	Navigation Radio																																																										
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																												
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																								
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																								
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																V	V																							
2	2012	Yukon	Chassis	Electronic Brake Control Module																																		V																						
2	2012	Yukon	Chassis	Electronic Suspension Control																																																								
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																								
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
2	2012	Yukon	Body	Amplifier (Bose)																																																								
2	2012	Yukon	Body	Assist Step Controller																																																								
2	2012	Yukon	Body	Body Control Module			V																																			V	V																	
2	2012	Yukon	Body	Body Control Module (aux.)																																																								
2	2012	Yukon	Body	Digital Radio Receiver																																																								
2	2012	Yukon	Body	Driver Door Switch																																				V	V	V																		
2	2012	Yukon	Body	HVAC Control Module Auto																																						V		V																
2	2012	Yukon	Body	HVAC Control Module Manual																																						V		V																
2	2012	Yukon	Body	Instrument Panel Cluster																																																								
2	2012	Yukon	Body	Left Side Object Detection Module																																																								
2	2012	Yukon	Body	Lift Gate Module																																				V																				
2	2012	Yukon	Body	Memory Seat Module																																																								
2	2012	Yukon	Body	Park Assist Module																																																								
2	2012	Yukon	Body	Passenger Door Switch																																				V	V	V																		
2	2012	Yukon	Body	Passenger Presence System																																				V																				
2	2012	Yukon	Body	Radio																																																								
2	2012	Yukon	Body	Navigation Radio																																																								
2	2012	Yukon	Body	Rear Heated Seat Module																																																								
2	2012	Yukon	Body	Rear HVAC/RSA																																																								
2	2012	Yukon	Body	Right Side Object Detection Module																																																								
2	2012	Yukon	Body	Supplemental Inflatable Restraint																																																								
2	2012	Yukon	Body	Theft Deterrent Module																																																								
2	2012	Yukon Hybrid	Powertrain	Engine Control Module																											V			V																										
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																								
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																								
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																								
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																								
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																								
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																								
2	2012	Yukon Hybrid	Body	Body Control Module			V																																			V	V																	
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																								
2	2012	Yukon Hybrid	Body	Driver Door Switch																																				V	V	V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2012	Yukon Hybrid	Body	Heated Seat Module																																																							
2	2012	Yukon Hybrid	Body	HVAC Control Module																																						V		V															
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																						
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																						
2	2012	Yukon Hybrid	Body	Lift Gate Module																																					V																		
2	2012	Yukon Hybrid	Body	Park Assist Module																																																						
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																					V	V	V																
2	2012	Yukon Hybrid	Body	Passenger Presence System																																					V																		
2	2012	Yukon Hybrid	Body	Radio																																																						
2	2012	Yukon Hybrid	Body	Navigation Radio																																																						
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																						
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																						
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																						
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																						
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																						
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																						
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																									
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																						
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																V	V																						
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																						
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																						
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																									
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																						
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																						
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																						
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																									
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																						
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																									
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																						
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																V	V																						
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																			V																			
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																						
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																						
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																						
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																						
2	2012	Yukon XL	Body	Amplifier (Bose)																																																						
2	2012	Yukon XL	Body	Assist Step Controller																																																						
2	2012	Yukon XL	Body	Body Control Module			V																																			V	V																
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																						
2	2012	Yukon XL	Body	Digital Radio Receiver																																																						
2	2012	Yukon XL	Body	Driver Door Switch																																					V	V	V																
2	2012	Yukon XL	Body	HVAC Control Module Auto																																						V		V															
2	2012	Yukon XL	Body	HVAC Control Module Manual																																						V		V															
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																						
2	2012	Yukon XL	Body	Left Side Object Detection Module																																																						
2	2012	Yukon XL	Body	Lift Gate Module																																					V																		
2	2012	Yukon XL	Body	Memory Seat Module																																																						
2	2012	Yukon XL	Body	Park Assist Module																																																						
2	2012	Yukon XL	Body	Passenger Door Switch																																					V	V	V																

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2012	Yukon XL	Body	Passenger Presence System																																						V																			
2	2012	Yukon XL	Body	Radio																																																								
2	2012	Yukon XL	Body	Navigation Radio																																																									
2	2012	Yukon XL	Body	Rear Heated Seat Module																																																									
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																									
2	2012	Yukon XL	Body	Right Side Object Detection Module																																																									
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
2	2012	Yukon XL	Body	Theft Deterrent Module																																																									
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																											
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																									
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																											
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																V	V	V		V	V	V											V																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																									
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																											
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																	V	V																							
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																									
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																	V	V																							
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																											
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																							
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																									
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																											
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																									
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																	V	V																							
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																									
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																											V		V	V																											
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																	V	V																							
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																									
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																											V			V																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																									
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																									
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																				V	V	V	V	V																																	
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																									
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																			V																						
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																									
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																									
2	2013	Sierra	Chassis	Electronic Suspension Control																																																									
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Sierra	Body	Amplifier (Bose)																																																									
2	2013	Sierra	Body	Body Control Module			V																																			V	V																		
2	2013	Sierra	Body	Body Control Module (aux.)																																																									
2	2013	Sierra	Body	Digital Radio Receiver																																																									
2	2013	Sierra	Body	Driver Door Switch																																						V	V	V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2013	Sierra	Body	HVAC Control Module Auto																																						V		V																
2	2013	Sierra	Body	HVAC Control Module Manual																																						V		V																
2	2013	Sierra	Body	Instrument Panel Cluster																																																								
2	2013	Sierra	Body	Memory Seat Module																																																								
2	2013	Sierra	Body	Park Assist Module																																																								
2	2013	Sierra	Body	Passenger Door Switch																																					V	V	V																		
2	2013	Sierra	Body	Passenger Presence System																																					V																				
2	2013	Sierra	Body	Radio																																																								
2	2013	Sierra	Body	Navigation Radio																																																								
2	2013	Sierra	Body	Rear Heated Seat Module																																																								
2	2013	Sierra	Body	Rear HVAC/RSA																																																								
2	2013	Sierra	Body	Supplemental Inflatable Restraint																																																								
2	2013	Sierra	Body	Theft Deterrent Module																																																								
2	2013	Sierra Hybrid	Powertrain	Engine Control Module																											V		V																												
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																								
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																								
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																								
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																								
2	2013	Sierra Hybrid	Body	Body Control Module			V																																			V	V																		
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																								
2	2013	Sierra Hybrid	Body	Driver Door Switch																																					V	V	V																		
2	2013	Sierra Hybrid	Body	Heated Seat Module																																																								
2	2013	Sierra Hybrid	Body	HVAC Control Module																																						V		V																		
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
2	2013	Sierra Hybrid	Body	Park Assist Module																																																								
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																					V	V	V																		
2	2013	Sierra Hybrid	Body	Passenger Presence System																																					V																				
2	2013	Sierra Hybrid	Body	Radio																																																								
2	2013	Sierra Hybrid	Body	Navigation Radio																																																								
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																											
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																							
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																	V	V																							
2	2013	Yukon	Chassis	Electronic Brake Control Module																																			V																						
2	2013	Yukon	Chassis	Electronic Suspension Control																																																								
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Yukon	Body	Amplifier (Bose)																																																								
2	2013	Yukon	Body	Assist Step Controller																																																								
2	2013	Yukon	Body	Body Control Module			V																																			V	V																		
2	2013	Yukon	Body	Body Control Module (aux.)																																																								
2	2013	Yukon	Body	Digital Radio Receiver																																																								
2	2013	Yukon	Body	Driver Door Switch																																					V	V	V																		
2	2013	Yukon	Body	HVAC Control Module Auto																																						V		V																	
2	2013	Yukon	Body	HVAC Control Module Manual																																						V		V																	
2	2013	Yukon	Body	Instrument Panel Cluster																																																								
2	2013	Yukon	Body	Left Side Object Detection Module																																																								
2	2013	Yukon	Body	Lift Gate Module																																					V																				
2	2013	Yukon	Body	Memory Seat Module																																																								
2	2013	Yukon	Body	Park Assist Module																																																								
2	2013	Yukon	Body	Passenger Door Switch																																					V	V	V																		
2	2013	Yukon	Body	Passenger Presence System																																					V																				
2	2013	Yukon	Body	Radio																																																								
2	2013	Yukon	Body	Navigation Radio																																																								
2	2013	Yukon	Body	Rear Heated Seat Module																																																								
2	2013	Yukon	Body	Rear HVAC/RSA																																																								
2	2013	Yukon	Body	Right Side Object Detection Module																																																								
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																																								
2	2013	Yukon	Body	Theft Deterrent Module																																																								
2	2013	Yukon Hybrid	Powertrain	Engine Control Module																											V		V																												
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																								
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																								
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																								
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																								
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																								
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																								
2	2013	Yukon Hybrid	Body	Body Control Module			V																																			V	V																		
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																								
2	2013	Yukon Hybrid	Body	Driver Door Switch																																					V	V	V																		
2	2013	Yukon Hybrid	Body	Heated Seat Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2013	Yukon Hybrid	Body	HVAC Control Module																																						V		V															
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																						
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																						
2	2013	Yukon Hybrid	Body	Lift Gate Module																																					V																		
2	2013	Yukon Hybrid	Body	Park Assist Module																																																						
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																					V	V	V																
2	2013	Yukon Hybrid	Body	Passenger Presence System																																					V																		
2	2013	Yukon Hybrid	Body	Radio																																																						
2	2013	Yukon Hybrid	Body	Navigation Radio																																																						
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																						
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																						
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																						
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																						
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																						
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																						
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																											V		V	V																									
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																						
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																V	V																						
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																						
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																						
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																											V		V	V																									
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																V	V																						
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																						
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																						
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																									
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																						
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																											V		V	V																									
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																						
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																V	V																						
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																			V																			
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																						
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																						
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																						
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																						
2	2013	Yukon XL	Body	Amplifier (Bose)																																																						
2	2013	Yukon XL	Body	Assist Step Controller																																																						
2	2013	Yukon XL	Body	Body Control Module			V																																			V	V																
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																						
2	2013	Yukon XL	Body	Digital Radio Receiver																																																						
2	2013	Yukon XL	Body	Driver Door Switch																																					V	V	V																
2	2013	Yukon XL	Body	HVAC Control Module Auto																																						V		V															
2	2013	Yukon XL	Body	HVAC Control Module Manual																																						V		V															
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																						
2	2013	Yukon XL	Body	Left Side Object Detection Module																																																						
2	2013	Yukon XL	Body	Lift Gate Module																																					V																		
2	2013	Yukon XL	Body	Memory Seat Module																																																						
2	2013	Yukon XL	Body	Park Assist Module																																																						
2	2013	Yukon XL	Body	Passenger Door Switch																																					V	V	V																
2	2013	Yukon XL	Body	Passenger Presence System																																					V																		

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2013	Yukon XL	Body	Radio																																																								
2	2013	Yukon XL	Body	Navigation Radio																																																								
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																								
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																								
2	2013	Yukon XL	Body	Right Side Object Detection Module																																																								
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
2	2013	Yukon XL	Body	Theft Deterrent Module																																																								
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																								
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2014	Sierra	Chassis	Electronic Brake Control Module																																																								
2	2014	Sierra	Chassis	Parking Brake Control Module																																																								
2	2014	Sierra	Chassis	Power Steering Control Module																																																								
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																								
2	2014	Sierra	Body	Body Control Module																																																								
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
2	2014	Sierra	Body	Passenger Presence Module																																																								
2	2014	Sierra	Body	Instrument Cluster																																																								
2	2014	Sierra	Body	Radio Control																																																								
2	2014	Sierra	Body	HVAC Control																																																								
2	2014	Sierra	Body	Radio																																																								
2	2014	Sierra	Body	Amplifier																																																								
2	2014	Sierra	Body	Media Disc Player																																																								
2	2014	Sierra	Body	Human Machine Interface Control Module																																																								
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																								
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																								
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																								
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																								
2	2014	Sierra	Body	Parking Assist Control Module																																																								
2	2014	Sierra	Body	Frontview Camera Module																																																								
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																								
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																								
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																								
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2014	Sierra HD	Chassis	Suspension Control Module																																																									
2	2014	Sierra HD	Body	Body Control Module																																																										
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Sierra HD	Body	Instrument Cluster																																																										
2	2014	Sierra HD	Body	Base Radio																																																										
2	2014	Sierra HD	Body	Navigation Radio																																																										
2	2014	Sierra HD	Body	Uplevel Radio																																																										
2	2014	Sierra HD	Body	Amplifier																																																										
2	2014	Sierra HD	Body	Rear Audio Control Module																																																										
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																										
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																										
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																										
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Sierra HD	Body	Seat Memory Control Module																																																										
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																										
2	2014	Sierra HD	Body	Parking Assist Control Module																																																										
2	2014	Sierra HD	Body	Theft Deterrent Module																																																										
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																										
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2014	Yukon	Chassis	Parking Brake Control Module																																																										
2	2014	Yukon	Chassis	Suspension Control Module																																																										
2	2014	Yukon	Body	Body Control Module																																																										
2	2014	Yukon	Body	Auxiliary Body Control Module																																																										
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Yukon	Body	Passenger Presence Module																																																										
2	2014	Yukon	Body	Instrument Cluster																																																										
2	2014	Yukon	Body	Base Radio																																																										
2	2014	Yukon	Body	Navigation Radio																																																										
2	2014	Yukon	Body	Uplevel Radio																																																										
2	2014	Yukon	Body	Amplifier																																																										
2	2014	Yukon	Body	Rear Audio Control Module																																																										
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																										
2	2014	Yukon	Body	Personal Audio Link Control Module																																																										
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																									
2	2014	Yukon	Body	Liftgate Control Module																																																										
2	2014	Yukon	Body	Seat Memory Control Module																																																										
2	2014	Yukon	Body	Rear Seat Heating Control Module																																																										
2	2014	Yukon	Body	Assist Step Control Module																																																										
2	2014	Yukon	Body	Right Side Object Detection Control Module																																																										
2	2014	Yukon	Body	Left Side Object Detection Control Module																																																										
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																										
2	2014	Yukon	Body	Parking Assist Control Module																																																										
2	2014	Yukon	Body	Theft Deterrent Module																																																										
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																										
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																										
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																										
2	2014	Yukon XL	Chassis	Suspension Control Module																																																										
2	2014	Yukon XL	Body	Body Control Module																																																										
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																										
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Yukon XL	Body	Passenger Presence Module																																																										
2	2014	Yukon XL	Body	Instrument Cluster																																																										
2	2014	Yukon XL	Body	Base Radio																																																										
2	2014	Yukon XL	Body	Navigation Radio																																																										
2	2014	Yukon XL	Body	Uplevel Radio																																																										
2	2014	Yukon XL	Body	Amplifier																																																										
2	2014	Yukon XL	Body	Rear Audio Control Module																																																										
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																										
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																										
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																										
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Yukon XL	Body	Liftgate Control Module																																																										
2	2014	Yukon XL	Body	Seat Memory Control Module																																																										
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																										
2	2014	Yukon XL	Body	Assist Step Control Module																																																										
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																										
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																										
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																										
2	2014	Yukon XL	Body	Parking Assist Control Module																																																										
2	2014	Yukon XL	Body	Theft Deterrent Module																																																										
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Sierra	Chassis	Electronic Brake Control Module																																																										
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Sierra	Chassis	Power Steering Control Module																																																										
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Sierra	Chassis	Suspension Control Module																																																										
2	2015	Sierra	Body	Body Control Module																																																										
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Sierra	Body	Passenger Presence Module																																																										
2	2015	Sierra	Body	Instrument Cluster																																																										
2	2015	Sierra	Body	Radio Controls																																																										
2	2015	Sierra	Body	HVAC Controls																																																										
2	2015	Sierra	Body	Radio																																																										
2	2015	Sierra	Body	Amplifier																																																										
2	2015	Sierra	Body	Media Disc Player																																																										
2	2015	Sierra	Body	Human Machine Interface Control Module																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2015	Sierra	Body	Parking Assist Control Module																																																										
2	2015	Sierra	Body	Frontview Camera Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																										
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																										
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																										
2	2015	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Yukon	Chassis	Parking Brake Control Module																																																										
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																										
2	2015	Yukon	Chassis	Power Steering Control Module																																																										
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Yukon	Chassis	Suspension Control Module																																																										
2	2015	Yukon	Body	Body Control Module																																																										
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Yukon	Body	Passenger Presence Module																																																										
2	2015	Yukon	Body	Instrument Cluster																																																										
2	2015	Yukon	Body	Radio Controls																																																										
2	2015	Yukon	Body	HVAC Controls																																																										
2	2015	Yukon	Body	Radio																																																										
2	2015	Yukon	Body	Amplifier																																																										
2	2015	Yukon	Body	Media Disc Player																																																										
2	2015	Yukon	Body	Human Machine Interface Control Module																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Yukon	Body	HVAC Control Module																																																										
2	2015	Yukon	Body	Liftgate Control Module																																																										
2	2015	Yukon	Body	Keyless Entry Control Module																																																										
2	2015	Yukon	Body	Assist Step Control Module																																																										
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																										
2	2015	Yukon	Body	Parking Assist Control Module																																																										
2	2015	Yukon	Body	Frontview Camera Module																																																										
2	2015	Yukon	Body	Steering Column Lock Control Module																																																										
2	2015	Yukon	Body	Battery Energy Control Module																																																										
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																								
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																									
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																									
2	2015	Yukon XL	Chassis	Power Steering Control Module																																																									
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2015	Yukon XL	Chassis	Suspension Control Module																																																									
2	2015	Yukon XL	Body	Body Control Module																																																									
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2015	Yukon XL	Body	Passenger Presence Module																																																									
2	2015	Yukon XL	Body	Instrument Cluster																																																									
2	2015	Yukon XL	Body	Radio Controls																																																									
2	2015	Yukon XL	Body	HVAC Controls																																																									
2	2015	Yukon XL	Body	Radio																																																									
2	2015	Yukon XL	Body	Amplifier																																																									
2	2015	Yukon XL	Body	Media Disc Player																																																									
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																									
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																									
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																									
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2015	Yukon XL	Body	HVAC Control Module																																																									
2	2015	Yukon XL	Body	Liftgate Control Module																																																									
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																									
2	2015	Yukon XL	Body	Assist Step Control Module																																																									
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																									
2	2015	Yukon XL	Body	Parking Assist Control Module																																																									
2	2015	Yukon XL	Body	Frontview Camera Module																																																									
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																									
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																									
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																									
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																									
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																									
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																									
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																									
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																									
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2016	Sierra	Chassis	Electronic Brake Control Module																																																									
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																									
2	2016	Sierra	Chassis	Parking Brake Control Module																																																									
2	2016	Sierra	Chassis	Power Steering Control Module																																																									
2	2016	Sierra	Chassis	Power Steering Control Module																																																									
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2016	Sierra	Chassis	Suspension Control Module																																																									
2	2016	Sierra	Body	Body Control Module																																																									
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2016	Sierra	Body	Passenger Presence Module																																																									
2	2016	Sierra	Body	Instrument Cluster																																																									
2	2016	Sierra	Body	Radio Controls																																																									
2	2016	Sierra	Body	HVAC Controls																																																									
2	2016	Sierra	Body	Radio (IO3)																																																									
2	2016	Sierra	Body	Radio (IOB)																																																									
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																									
2	2016	Sierra	Body	Amplifier																																																									
2	2016	Sierra	Body	Media Disc Player																																																									
2	2016	Sierra	Body	Human Machine Interface Control Module																																																									
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																									
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																									
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																									
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																									
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																									
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																									
2	2016	Sierra	Body	Parking Assist Control Module																																																									
2	2016	Sierra	Body	Frontview Camera Module																																																									
2	2016	Sierra	Body	Frontview Camera Module																																																									
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2016	Yukon	Chassis	Electronic Brake Control Module																																																									
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																									
2	2016	Yukon	Chassis	Parking Brake Control Module																																																									
2	2016	Yukon	Chassis	Power Steering Control Module																																																									
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2016	Yukon	Chassis	Suspension Control Module																																																									
2	2016	Yukon	Body	Body Control Module																																																									
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2016	Yukon	Body	Passenger Presence Module																																																									
2	2016	Yukon	Body	Instrument Cluster																																																									
2	2016	Yukon	Body	Radio Controls																																																									
2	2016	Yukon	Body	HVAC Controls																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
2	2016	Yukon	Body	Radio																																																								
2	2016	Yukon	Body	Amplifier																																																								
2	2016	Yukon	Body	Media Disc Player																																																								
2	2016	Yukon	Body	Human Machine Interface Control Module																																																								
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																								
2	2016	Yukon	Body	HVAC Control Module																																																								
2	2016	Yukon	Body	Liftgate Control Module																																																								
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																								
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																								
2	2016	Yukon	Body	Keyless Entry Control Module																																																								
2	2016	Yukon	Body	Assist Step Control Module																																																								
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																								
2	2016	Yukon	Body	Parking Assist Control Module																																																								
2	2016	Yukon	Body	Frontview Camera Module																																																								
2	2016	Yukon	Body	Steering Column Lock Control Module																																																								
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																								
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																								
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																								
2	2016	Yukon XL	Chassis	Power Steering Control Module																																																								
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																								
2	2016	Yukon XL	Chassis	Suspension Control Module																																																								
2	2016	Yukon XL	Body	Body Control Module																																																								
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
2	2016	Yukon XL	Body	Passenger Presence Module																																																								
2	2016	Yukon XL	Body	Instrument Cluster																																																								
2	2016	Yukon XL	Body	Radio Controls																																																								
2	2016	Yukon XL	Body	HVAC Controls																																																								
2	2016	Yukon XL	Body	Radio																																																								
2	2016	Yukon XL	Body	Amplifier																																																								
2	2016	Yukon XL	Body	Media Disc Player																																																								
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																								
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																								
2	2016	Yukon XL	Body	HVAC Control Module																																																								
2	2016	Yukon XL	Body	Liftgate Control Module																																																								
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																								
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																								
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																								
2	2016	Yukon XL	Body	Assist Step Control Module																																																								
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																								
2	2016	Yukon XL	Body	Parking Assist Control Module																																																								
2	2016	Yukon XL	Body	Frontview Camera Module																																																								
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																								
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																										
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module															V	V	V		V	V	V											V																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																							
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																							
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																							
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																											V		V	V																									
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																V	V	V		V	V	V											V																							
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																							
5	2011	ALL	Chassis	Electronic Brake Control Module																																			V																					
5	2011	ALL	Body	Body Control Module																																					V	V	V																	
5	2011	ALL	Body	Digital Radio Receiver																																																							
5	2011	ALL	Body	Generator Battery Control Module																																																							
5	2011	ALL	Body	Instrument Panel Cluster																																					V	V																	
5	2011	ALL	Body	Passenger Presence System																																																							
5	2011	ALL	Body	Personal Audio Link Module																																																							
5	2011	ALL	Body	Base Radio																																																							
5	2011	ALL	Body	Uplevel Radio																																																							
5	2011	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
5	2011	ALL	Body	Theft Deterrent Module																																					V																		
5	2011	ALL	Body	Vehicle Comm. Interface Module																																																							
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																									
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V											V																							
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																							
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V											V																							
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																							
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																											V		V	V																									
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																V	V	V		V	V	V											V																							
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																							
5	2012	ALL	Chassis	Electronic Brake Control Module																																			V																					
5	2012	ALL	Body	Body Control Module																																					V	V	V																	
5	2012	ALL	Body	Digital Radio Receiver																																																							
5	2012	ALL	Body	Generator Battery Control Module																																																							
5	2012	ALL	Body	Instrument Panel Cluster																																					V	V																	
5	2012	ALL	Body	Passenger Presence System																																																							
5	2012	ALL	Body	Personal Audio Link Module																																																							
5	2012	ALL	Body	Base Radio																																																							
5	2012	ALL	Body	Uplevel Radio																																																							
5	2012	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
5	2012	ALL	Body	Theft Deterrent Module																																					V																		
5	2012	ALL	Body	Vehicle Comm. Interface Module																																																							
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																							
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																							
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																							
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																							
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																							
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																							
5	2015	Canyon	Powertrain	Chassis Control Module																																																							
5	2015	Canyon	Powertrain	Transfer Case Control Module																																																							
5	2015	Canyon	Chassis	Electronic Brake Control Module																																																							
5	2015	Canyon	Chassis	Power Steering Control Module																																																							
5	2015	Canyon	Body	Body Control Module																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
5	2015	Canyon	Body	Passenger Presence Module																																																								
5	2015	Canyon	Body	Radio																																																								
5	2015	Canyon	Body	Amplifier																																																								
5	2015	Canyon	Body	Human Machine Interface Control Module																																																								
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																																								
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																								
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																								
5	2015	Canyon	Body	Parking Assist Control Module																																																								
5	2015	Canyon	Body	Frontview Camera Module																																																								
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																								
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
5	2016	Canyon	Powertrain	Transfer Case Control Module																																																								
5	2016	Canyon	Chassis	Electronic Brake Control Module																																																								
5	2016	Canyon	Chassis	Power Steering Control Module																																																								
5	2016	Canyon	Body	Body Control Module																																																								
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
5	2016	Canyon	Body	Passenger Presence Module																																																								
5	2016	Canyon	Body	Trailer Interface Control Module																																																								
5	2016	Canyon	Body	Radio																																																								
5	2016	Canyon	Body	Amplifier																																																								
5	2016	Canyon	Body	Human Machine Interface Control Module																																																								
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																																								
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																								
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																								
5	2016	Canyon	Body	Frontview Camera Module																																																								
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module														V	V	V		V	V	V												V																								
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module														V	V	V		V	V	V												V																								
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																											V		V	V																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module														V	V	V		V	V	V												V																								
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																								
6	2011	ALL	Chassis	Electronic Brake Control Module																																			V																					
6	2011	ALL	Body	Body Control Module																																					V	V	V																	
6	2011	ALL	Body	Digital Radio Receiver																																																								
6	2011	ALL	Body	Generator Battery Control Module																																																								
6	2011	ALL	Body	Instrument Panel Cluster																																					V	V																		
6	2011	ALL	Body	Passenger Presence System																																																								
6	2011	ALL	Body	Personal Audio Link Module																																																								
6	2011	ALL	Body	Base Radio																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
6	2011	ALL	Body	Uplevel Radio																																																							
6	2011	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
6	2011	ALL	Body	Theft Deterrent Module																																					V																		
6	2011	ALL	Body	Vehicle Comm. Interface Module																																																							
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																											V	V	V	V																									
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																V	V	V		V	V	V										V																							
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																							
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																							
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																											V	V	V	V																									
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V										V																							
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																							
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																							
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																											V		V	V																									
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																V	V	V		V	V	V										V																							
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																							
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																							
6	2012	ALL	Chassis	Electronic Brake Control Module																																			V																				
6	2012	ALL	Body	Body Control Module																																					V	V	V																
6	2012	ALL	Body	Digital Radio Receiver																																																							
6	2012	ALL	Body	Generator Battery Control Module																																																							
6	2012	ALL	Body	Instrument Panel Cluster																																					V	V																	
6	2012	ALL	Body	Passenger Presence System																																																							
6	2012	ALL	Body	Personal Audio Link Module																																																							
6	2012	ALL	Body	Base Radio																																																							
6	2012	ALL	Body	Uplevel Radio																																																							
6	2012	ALL	Body	Supplemental Inflatable Restraint																																					V																		V
6	2012	ALL	Body	Theft Deterrent Module																																					V																		
6	2012	ALL	Body	Vehicle Comm. Interface Module																																																							
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																							
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																							
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																							
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																							
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																							
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																							
6	2015	Canyon	Powertrain	Chassis Control Module																																																							
6	2015	Canyon	Powertrain	Transfer Case Control Module																																																							
6	2015	Canyon	Chassis	Electronic Brake Control Module																																																							
6	2015	Canyon	Chassis	Power Steering Control Module																																																							
6	2015	Canyon	Body	Body Control Module																																																							
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
6	2015	Canyon	Body	Passenger Presence Module																																																							
6	2015	Canyon	Body	Radio																																																							
6	2015	Canyon	Body	Amplifier																																																							
6	2015	Canyon	Body	Human Machine Interface Control Module																																																							
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																																							
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																							
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																							
6	2015	Canyon	Body	Parking Assist Control Module																																																							
6	2015	Canyon	Body	Frontview Camera Module																																																							
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																							
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History & Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
6	2016	Canyon	Powertrain	Transfer Case Control Module																																																										
6	2016	Canyon	Chassis	Electronic Brake Control Module																																																										
6	2016	Canyon	Chassis	Power Steering Control Module																																																										
6	2016	Canyon	Body	Body Control Module																																																										
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
6	2016	Canyon	Body	Passenger Presence Module																																																										
6	2016	Canyon	Body	Trailer Interface Control Module																																																										
6	2016	Canyon	Body	Radio																																																										
6	2016	Canyon	Body	Amplifier																																																										
6	2016	Canyon	Body	Human Machine Interface Control Module																																																										
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																																										
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
6	2016	Canyon	Body	Frontview Camera Module																																																										
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																												
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																												
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																								
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																												
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																								
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																												
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																								
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																												
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																	V	V																								
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																												
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																	V	V																								
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2011	Express/Savana	Body	Body Control Module			V																																				V	V																		
7	2011	Express/Savana	Body	Digital Radio Receiver																																																										
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
7	2011	Express/Savana	Body	Passenger Presence System																																						V																				
7	2011	Express/Savana	Body	Radio																																																									
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
7	2011	Express/Savana	Body	Rollover Sensor																																																										
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																						V																				
7	2011	Express/Savana	Body	Theft Deterrent Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																												
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																								
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																												
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																								
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																												
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																							
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																										
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																						
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																V	V																						
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																						
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																						
7	2011	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V																	
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																						
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																					V																			
7	2011	Express Access/Savana Pro	Body	Radio																																																						
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																						
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																			
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																						
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																						
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																							
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																										
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																						
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																V	V																						
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																						
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																						
7	2012	Express/Savana	Body	Body Control Module			V																																			V	V																	
7	2012	Express/Savana	Body	Digital Radio Receiver																																																						
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																						
7	2012	Express/Savana	Body	Passenger Presence System																																					V																			
7	2012	Express/Savana	Body	Radio																																																						
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
7	2012	Express/Savana	Body	Rollover Sensor																																																						
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																			
7	2012	Express/Savana	Body	Theft Deterrent Module																																																						
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																							
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																						
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																						
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																										
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																	V	V																						
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																							
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																	V	V																						
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																						
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																						
7	2012	Express Access/Savana Pro	Body	Body Control Module			V																																				V	V																
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																						
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																					V																			
7	2012	Express Access/Savana Pro	Body	Radio																																																						
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																						
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																						
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																						
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																						
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																						
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																	V	V																						
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																										
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																	V	V																						
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																	V	V																						
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																						
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																						
7	2013	Express/Savana	Body	Body Control Module			V																																				V	V																
7	2013	Express/Savana	Body	Digital Radio Receiver																																																						
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																						
7	2013	Express/Savana	Body	Passenger Presence System																																					V																			
7	2013	Express/Savana	Body	Radio																																																						
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
7	2013	Express/Savana	Body	Rollover Sensor																																																						
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		
7	2013	Express/Savana	Body	Theft Deterrent Module																																																						
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																											V		V	V																										
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																V	V	V		V	V	V											V																						
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																							
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																							
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																										
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																							
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																							
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																											V			V																										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																V	V																							
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																						
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																						
7	2013	Express Access/Savana Pro	Body	Body Control Module			V																																				V	V																
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																						
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																						
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																						
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																					V																			
7	2013	Express Access/Savana Pro	Body	Radio																																																						
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																						
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																			
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																						
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																						
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																						
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																						
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																						
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																						
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																						
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																						
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																						
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																						
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																						
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																						
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																						
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																						
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																						
7	2014	Savana	Chassis	Electronic Brake Control Module																																																						
7	2014	Savana	Body	Body Control Module																																																						
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
7	2014	Savana	Body	Passenger Presence Module																																																						
7	2014	Savana	Body	Rollover Sensor Module																																																						
7	2014	Savana	Body	Instrument Cluster																																																						
7	2014	Savana	Body	Chime Alarm Control Module																																																						
7	2014	Savana	Body	Base Radio																																																						
7	2014	Savana	Body	Navigation Radio																																																						
7	2014	Savana	Body	Uplevel Radio																																																						
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																						
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																						
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
7	2014	Savana	Body	Auxiliary Heater Control Module																																																								
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																								
7	2014	Savana	Body	Parking Assist Control Module																																																								
7	2014	Savana	Body	Theft Deterrent Module																																																								
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
7	2015	Savana	Chassis	Electronic Brake Control Module																																																								
7	2015	Savana	Body	Body Control Module																																																								
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
7	2015	Savana	Body	Rollover Sensor Module																																																								
7	2015	Savana	Body	Instrument Cluster																																																								
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																								
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																								
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																								
7	2015	Savana	Body	Auxiliary Heater Control Module																																																								
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																								
7	2015	Savana	Body	Parking Assist Control Module																																																								
7	2015	Savana	Body	Theft Deterrent Module																																																								
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
7	2016	Savana	Chassis	Electronic Brake Control Module																																																								
7	2016	Savana	Body	Body Control Module																																																								
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
7	2016	Savana	Body	Instrument Cluster																																																								
7	2016	Savana	Body	Chime Alarm Control Module																																																								
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																								
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																								
7	2016	Savana	Body	Auxiliary Heater Control Module																																																								
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																								
7	2016	Savana	Body	Parking Assist Control Module																																																								
7	2016	Savana	Body	Theft Deterrent Module																																																								
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																												V		V	V																									
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																	V	V																						
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																												V		V	V																									
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V											V																							
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																												V		V	V																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																										V		V	V																										
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																						
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																						
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																						
8	2011	Express/Savana	Body	Body Control Module			V																																			V	V																
8	2011	Express/Savana	Body	Digital Radio Receiver																																																						
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																						
8	2011	Express/Savana	Body	Passenger Presence System																																					V																		
8	2011	Express/Savana	Body	Radio																																																						
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
8	2011	Express/Savana	Body	Rollover Sensor																																																						
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																		
8	2011	Express/Savana	Body	Theft Deterrent Module																																																						
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																										V		V	V																										
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																						
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																										
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																							
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																										V		V	V																										
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																										V		V	V																										
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																						
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																						
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																						
8	2011	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V																
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																						
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																					V																		
8	2011	Express Access/Savana Pro	Body	Radio																																																						
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																						
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																						
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																										V		V	V																										
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																						
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																										V		V	V																										
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																							
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																										V		V	V																										
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																										V		V	V																										
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																						
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																						
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																						
8	2012	Express/Savana	Body	Body Control Module			V																																			V	V																
8	2012	Express/Savana	Body	Digital Radio Receiver																																																						
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																						
8	2012	Express/Savana	Body	Passenger Presence System																																					V																		
8	2012	Express/Savana	Body	Radio																																																						
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																						

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
8	2012	Express/Savana	Body	Rollover Sensor																																																								
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																			
8	2012	Express/Savana	Body	Theft Deterrent Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																							
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																								
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																							
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																										
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																							
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
8	2012	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V																	
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																					V																			
8	2012	Express Access/Savana Pro	Body	Radio																																																								
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																			
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																							
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																								
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																							
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																											V		V	V																										
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																							
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
8	2013	Express/Savana	Body	Body Control Module			V																																			V	V																	
8	2013	Express/Savana	Body	Digital Radio Receiver																																																								
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
8	2013	Express/Savana	Body	Navigation Radio																																																								
8	2013	Express/Savana	Body	Park Assist Module																																																								
8	2013	Express/Savana	Body	Passenger Presence System																																					V																			
8	2013	Express/Savana	Body	Radio																																																								
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
8	2013	Express/Savana	Body	Rollover Sensor																																																								
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																					V																			
8	2013	Express/Savana	Body	Theft Deterrent Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																											V		V	V																										
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																V	V																							
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																											V		V	V																										
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																V	V	V		V	V	V										V																								
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																											V		V	V																										

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																V	V																						
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																										V		V	V																									
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																V	V																					
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																					
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																					
8	2013	Express Access/Savana Pro	Body	Body Control Module			V																																			V	V															
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																					
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																					
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																					
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																																					
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																					V																		
8	2013	Express Access/Savana Pro	Body	Radio																																																					
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																					
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																					
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																					V																		
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																					
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																					
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																					
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																					
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																					
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																					
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																					
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																					
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																					
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																					
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																					
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																					
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																					
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																					
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																					
8	2014	Savana	Chassis	Electronic Brake Control Module																																																					
8	2014	Savana	Body	Body Control Module																																																					
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																					
8	2014	Savana	Body	Passenger Presence Module																																																					
8	2014	Savana	Body	Rollover Sensor Module																																																					
8	2014	Savana	Body	Instrument Cluster																																																					
8	2014	Savana	Body	Chime Alarm Control Module																																																					
8	2014	Savana	Body	Base Radio																																																					
8	2014	Savana	Body	Navigation Radio																																																					
8	2014	Savana	Body	Uplevel Radio																																																					
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																					
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																					
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																					
8	2014	Savana	Body	Auxiliary Heater Control Module																																																					
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																					
8	2014	Savana	Body	Parking Assist Control Module																																																					
8	2014	Savana	Body	Theft Deterrent Module																																																					
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																					
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																					
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																					
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																					

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																									
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
8	2015	Savana	Chassis	Electronic Brake Control Module																																																									
8	2015	Savana	Body	Body Control Module																																																								
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
8	2015	Savana	Body	Rollover Sensor Module																																																								
8	2015	Savana	Body	Instrument Cluster																																																								
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																								
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																								
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																								
8	2015	Savana	Body	Auxiliary Heater Control Module																																																								
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																								
8	2015	Savana	Body	Parking Assist Control Module																																																								
8	2015	Savana	Body	Theft Deterrent Module																																																								
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
8	2016	Savana	Chassis	Electronic Brake Control Module																																																								
8	2016	Savana	Body	Body Control Module																																																								
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
8	2016	Savana	Body	Instrument Cluster																																																								
8	2016	Savana	Body	Chime Alarm Control Module																																																								
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																								
8	2016	Savana	Body	Telematics Communication Interface Control Module																																																								
8	2016	Savana	Body	Auxiliary Heater Control Module																																																								
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																								
8	2016	Savana	Body	Parking Assist Control Module																																																								
8	2016	Savana	Body	Theft Deterrent Module																																																								
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module													V	V																																										
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																V	V	V		V	V	V																																	
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																								
ALL	2004	ALL	Chassis	ABS																																																								
ALL	2004	ALL	Chassis	Air Suspension																																																								
ALL	2004	ALL	Body	Amplifier (Bose)																																																								
ALL	2004	ALL	Body	Body Control Module																																					V	V	V																	
ALL	2004	ALL	Body	Digital Radio Receiver																																																								
ALL	2004	ALL	Body	Driver Door Module																																					V	V	V																	
ALL	2004	ALL	Body	Driver Seat Module																																																								
ALL	2004	ALL	Body	Heating and Air Conditioning																																																								
ALL	2004	ALL	Body	Instrument Panel Cluster																																																								
ALL	2004	ALL	Body	OnStar																																																								
ALL	2004	ALL	Body	Passenger Door Module																																					V	V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
ALL	2004	ALL	Body	Uplevel Radio																																																									
ALL	2004	ALL	Body	Navigation Radio																																																									
ALL	2004	ALL	Body	Rear Seat Audio																																					V																				
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																					V	V																			
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module													V	V																																										
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																V	V	V		V	V	V																																		
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									
ALL	2005	ALL	Chassis	ABS																																																									
ALL	2005	ALL	Chassis	Air Suspension																																																									
ALL	2005	ALL	Body	Body Control Module																																					V	V	V																			
ALL	2005	ALL	Body	Digital Radio Receiver																																																									
ALL	2005	ALL	Body	Driver Door Module (SUV)																																					V	V	V																			
ALL	2005	ALL	Body	Driver Door Module (SUT)																																					V	V	V																			
ALL	2005	ALL	Body	Driver Seat Module																																																									
ALL	2005	ALL	Body	Heating and Air Conditioning																																																									
ALL	2005	ALL	Body	Instrument Panel Cluster																																																									
ALL	2005	ALL	Body	Passenger Door Module																																					V	V	V																			
ALL	2005	ALL	Body	Uplevel Radio																																																									
ALL	2005	ALL	Body	Navigation Radio																																																									
ALL	2005	ALL	Body	Rear Seat Audio																																					V																				
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																					V																				V
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module													V	V																																											
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																V	V	V		V	V	V																																			
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									
ALL	2006	H2	Chassis	ABS																																																									
ALL	2006	H2	Chassis	Air Suspension																																																									
ALL	2006	H2	Body	Body Control Module																																					V	V	V																			
ALL	2006	H2	Body	Digital Radio Receiver																																																									
ALL	2006	H2	Body	Driver Door Module (SUV)																																					V	V	V																			
ALL	2006	H2	Body	Driver Door Module (SUT)																																					V	V	V																			
ALL	2006	H2	Body	Driver Seat Module																																																									
ALL	2006	H2	Body	Heating and Air Conditioning																																																									
ALL	2006	H2	Body	Instrument Panel Cluster																																																									
ALL	2006	H2	Body	Passenger Door Module																																					V	V	V																			
ALL	2006	H2	Body	Uplevel Radio																																																									
ALL	2006	H2	Body	Navigation Radio																																																									
ALL	2006	H2	Body	Rear Seat Audio																																					V																				
ALL	2006	H2	Body	Supplemental Inflatable Restraint																																					V																				V
ALL	2006	H3	Powertrain	Engine Control Module																													V	V																												
ALL	2006	H3	Powertrain	Transmission Control Module																V	V	V		V	V	V																																			
ALL	2006	H3	Powertrain	Transfer Case Control Module																																																									
ALL	2006	H3	Chassis	Antilock Brake System																																			V																					
ALL	2006	H3	Body	Body Control Module																																					V	V	V																			
ALL	2006	H3	Body	Digital Radio Receiver																																																									
ALL	2006	H3	Body	Instrument Panel Cluster																																					V	V																			
ALL	2006	H3	Body	Uplevel Radio																																																									V
ALL	2006	H3	Body	Navigation Radio																																																									
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																					V																				V
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module													V	V																																											
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																V	V	V		V	V	V																																			
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
ALL	2007	H2	Chassis	ABS																																																								
ALL	2007	H2	Chassis	Air Suspension																																																								
ALL	2007	H2	Body	Amplifier (Bose)																																																								
ALL	2007	H2	Body	Body Control Module																																					V	V	V																	
ALL	2007	H2	Body	Digital Radio Receiver																																																								
ALL	2007	H2	Body	Driver Door Module (SUV)																																					V	V	V																	
ALL	2007	H2	Body	Driver Door Module (SUT)																																					V	V	V																	
ALL	2007	H2	Body	Driver Seat Module																																																								
ALL	2007	H2	Body	HVAC Control Module																																																								
ALL	2007	H2	Body	Instrument Panel Cluster																																																								
ALL	2007	H2	Body	Passenger Door Module																																					V	V	V																	
ALL	2007	H2	Body	Uplevel Radio																																																								
ALL	2007	H2	Body	Navigation Radio																																																								
ALL	2007	H2	Body	Rear Seat Audio																																					V																			
ALL	2007	H2	Body	Supplemental Inflatable Restraint																																					V																			V
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																																								
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																											V		V	V																										
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V																																		
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																								
ALL	2007	H3	Chassis	EBCM																																		V																					
ALL	2007	H3	Body	Body Control Module (5GT)																																					V	V	V																	
ALL	2007	H3	Body	Body Control Module (ADM)																																					V	V	V																	
ALL	2007	H3	Body	Digital Radio Receiver																																																								
ALL	2007	H3	Body	Generator Battery Control Module																																																								
ALL	2007	H3	Body	Instrument Panel Cluster																																					V	V																		
ALL	2007	H3	Body	Personal Audio Link Module																																																								
ALL	2007	H3	Body	Uplevel Radio																																																								V
ALL	2007	H3	Body	Navigation Radio																																																								
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																					V																			V
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																																								
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																											V		V	V																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																								
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																V	V																							
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																								
ALL	2008	H2	Chassis	Air SCM																																																								
ALL	2008	H2	Chassis	EBCM																																																								
ALL	2008	H2	Body	Amplifier (Bose)																																																								
ALL	2008	H2	Body	Body Control Module			V																																			V	V																	
ALL	2008	H2	Body	Digital Radio Receiver																																																								
ALL	2008	H2	Body	Driver Door Switch																																					V	V	V																	
ALL	2008	H2	Body	HVAC Control Module																																						V		V																
ALL	2008	H2	Body	Instrument Panel Cluster																																																								
ALL	2008	H2	Body	Memory Seat Module																																																								
ALL	2008	H2	Body	Passenger Door Switch																																					V	V	V																	
ALL	2008	H2	Body	Radio																																																								
ALL	2008	H2	Body	Rear Heated Seat Module																																																								
ALL	2008	H2	Body	Rear HVAC/RSA																																																								
ALL	2008	H2	Body	Rollover Sensor																																																								
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																					V																			
ALL	2008	H2	Body	Theft Deterrent Module																																																								
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																																								

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)																										V	V	V	V																									
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																										V	V	V	V																									
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																V	V	V		V												V																							
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																						
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module																										V		V	V																									
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																V	V	V		V												V																							
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																																						
ALL	2008	H3	Chassis	EBCM																																		V																				
ALL	2008	H3	Body	Body Control Module (5GT)																																				V	V	V																
ALL	2008	H3	Body	Body Control Module (ADM)																																				V	V	V																
ALL	2008	H3	Body	Digital Radio Receiver																																																						
ALL	2008	H3	Body	Generator Battery Control Module																																																						
ALL	2008	H3	Body	Instrument Panel Cluster																																				V	V																	
ALL	2008	H3	Body	Personal Audio Link Module																																																						
ALL	2008	H3	Body	Uplevel Radio																																																						V
ALL	2008	H3	Body	Navigation Radio																																																						
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																				V																		V
ALL	2008	H3	Body	Theft Deterrent Module																																				V																		
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																																						
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																										V		V	V																									
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																						
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																V	V																						
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																						
ALL	2009	H2	Chassis	Air SCM																																																						
ALL	2009	H2	Chassis	EBCM																																																						
ALL	2009	H2	Body	Amplifier (Bose)																																																						
ALL	2009	H2	Body	Body Control Module			V																																			V	V															
ALL	2009	H2	Body	Digital Radio Receiver																																																						
ALL	2009	H2	Body	Driver Door Switch																																				V	V	V																
ALL	2009	H2	Body	HVAC Control Module																																						V		V														
ALL	2009	H2	Body	Instrument Panel Cluster																																																						
ALL	2009	H2	Body	Memory Seat Module																																																						
ALL	2009	H2	Body	Passenger Door Switch																																				V	V	V																
ALL	2009	H2	Body	Radio																																																						
ALL	2009	H2	Body	Rear Heated Seat Module																																																						
ALL	2009	H2	Body	Rear HVAC/RSA																																																						
ALL	2009	H2	Body	Rollover Sensor																																																						
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																				V																		
ALL	2009	H2	Body	Theft Deterrent Module																																																						
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																						
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																						
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)																										V	V	V	V																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																										V	V	V	V																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																						
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V										V																							
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																						
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																						
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)																										V		V	V																									
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)																										V		V	V																									
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																						
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																V	V	V		V	V	V										V																							

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																																								
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																																								
ALL	2009	H3	Chassis	EBCM																																		V																						
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																				V	V	V																		
ALL	2009	H3	Body	Body Control Module (ADM)																																				V	V	V																		
ALL	2009	H3	Body	Digital Radio Receiver																																																							
ALL	2009	H3	Body	Generator Battery Control Module																																																							
ALL	2009	H3	Body	Instrument Panel Cluster																																				V	V																		
ALL	2009	H3	Body	Personal Audio Link Module																																																							
ALL	2009	H3	Body	Uplevel Radio																																																							V
ALL	2009	H3	Body	Navigation Radio																																																						
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																				V																			V
ALL	2009	H3	Body	Theft Deterrent Module																																				V																		
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																																						
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																										V		V	V																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																						
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																V	V																						
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																						
ALL	2010	H2	Chassis	Air SCM																																																						
ALL	2010	H2	Chassis	EBCM																																																						
ALL	2010	H2	Body	Amplifier (Bose)																																																						
ALL	2010	H2	Body	Body Control Module			V																																		V	V																	
ALL	2010	H2	Body	Digital Radio Receiver																																																						
ALL	2010	H2	Body	Driver Door Switch																																				V	V	V																	
ALL	2010	H2	Body	HVAC Control Module																																					V		V																
ALL	2010	H2	Body	Instrument Panel Cluster																																																						
ALL	2010	H2	Body	Memory Seat Module																																																						
ALL	2010	H2	Body	Passenger Door Switch																																				V	V	V																	
ALL	2010	H2	Body	Personal Audio Link Module																																																						
ALL	2010	H2	Body	Radio																																																						
ALL	2010	H2	Body	Rear Heated Seat Module																																																						
ALL	2010	H2	Body	Rear HVAC/RSA																																																						
ALL	2010	H2	Body	Rollover Sensor																																																						
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																				V																		
ALL	2010	H2	Body	Theft Deterrent Module																																																						
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																																						
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																										V	V	V	V																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																						
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																V	V	V		V	V	V										V																							
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																						
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																						
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module																										V		V	V																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																						
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																V	V	V		V	V	V										V																							
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																																						
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																																						
ALL	2010	H3	Chassis	EBCM																																		V																				
ALL	2010	H3	Body	Body Control Module																																				V	V	V																	
ALL	2010	H3	Body	Digital Radio Receiver																																																						
ALL	2010	H3	Body	Generator Battery Control Module																																																						
ALL	2010	H3	Body	Instrument Panel Cluster																																				V	V																	

Engine type	Year	Model	System 1	System 2	Distance Sensing Cruise Control Disengage History 6 Data	Long Range Radar Sensor Module Learn	Interior Lighting	Seat Belt Retractor Motor Module Data	Reset History Buffer	Rear Axle Disable Data	Gear Position Sensor Learn	All Cameras Alignment Learn	Front Camera Alignment Learn	Left Camera Alignment Learn	Right Camera Alignment Learn	Rear Camera Alignment Learn	Engine Data 1	Engine Data 2	Engine Data 3	1-2 Shift Data	2-3 Shift Data	3-4 Shift Data	4-5 Shift Data	PC Solenoid Data	1-2 Adapt. Data	2-3 Adapt. Data	3-4 Adapt. Data	4-5 Adapt. Data	Steady State Data	Trans. Adaptives Reset	Cooling/HVAC Data	Cruise/Traction Data	Electrical/Theft Data	IPC Data	ODM Data	PC Solenoid	Reset Transmission Adapts.	Reset Transmission Oil Life	ABS/DRP/TCS Data	VSES Data	BAS System Data	Data	Inputs	Outputs	HVAC Door Positions	A/C Compressor Data	Lighting Data	Non - HVAC Data	Open/Short Data	RVC Data	Set Options	New VIN	Module Information	Door Zone Module VIN Relearn	Sensor Data 1	Sensor Data 2	Perimeter Lighting	Automatic Door Lock Mode	CTD Alarm Triggers	System Configuration
ALL	2010	H3	Body	Personal Audio Link Module																																																										
ALL	2010	H3	Body	Uplevel Radio																																																										V
ALL	2010	H3	Body	Navigation Radio																																																									
ALL	2010	H3	Body	Supplemental Inflatable Restraint																																					V																				V
ALL	2010	H3	Body	Theft Deterrent Module																																					V																				
ALL	2010	H3	Body	Vehicle Comm. Interface Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM			V	V	V																																																					
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM			V	V	V																																																					
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM			V	V	V																																																					
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																					
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																					
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module			V	V	V																																																					
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module					V																																																					
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module				V	V																																																					
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module				V	V																																																					
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module					V																																																					
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module			V	V	V																																																					
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																			V																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto																			V																																								
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																			V																																								
C	2004	ALL	Body	Instrument Panel Cluster																																																											
C	2004	ALL	Body	OnStar																																																	V	V								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Radio Base																																																										
C	2004	ALL	Body	Radio Uplevel																																																										
C	2004	ALL	Body	Radio Navigation								V																																																	
C	2004	ALL	Body	Rear Aux. Climate Module																																																										
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																										
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2004	ALL	Body	Vehicle Theft Deterrent		V																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM			V	V	V																																																					
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM			V	V	V																																																					
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM			V	V	V																																																					
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																					
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module			V	V	V																																																					
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																					
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module			V	V	V																																																					
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module					V																																																					
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module				V	V																																																					
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module				V	V																																																					
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module			V	V	V																																																					
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2005	ALL	Chassis	ESC																																																									
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2005	ALL	Chassis	VSES																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2005	ALL	Body	Amplifier (Bose)																																																									
C	2005	ALL	Body	Body Control Module																																																									
C	2005	ALL	Body	CD Changer																																																									
C	2005	ALL	Body	Chime																																																									
C	2005	ALL	Body	Disc Player and Video Display																																																									
C	2005	ALL	Body	Driver Door Module																																																									
C	2005	ALL	Body	Driver Seat Module																			V																																							
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																			V																																							
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2005	ALL	Body	Heating and Air Conditioning Manual																			V																																							
C	2005	ALL	Body	Instrument Panel Cluster																																																										
C	2005	ALL	Body	Passenger Door Module																																																										
C	2005	ALL	Body	Passenger Presence System																																																										
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio								V																																																	
C	2005	ALL	Body	Rear Aux. Climate Module																																																										
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																	V	V								
C	2005	ALL	Body	Vehicle Theft Deterrent		V																																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM			V	V	V																																																					
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM			V	V	V																																																					
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM			V	V	V																																																					
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																					
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module			V	V	V																																																					
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																					
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module			V	V	V																																																					
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module					V																																																					
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module				V	V																																																					
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module				V	V																																																					
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module					V																																																					
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																										
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																			
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module			V	V	V																																																				
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																									
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																									
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																									
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																									
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																									
C	2006	ALL	Chassis	VSES																																																									
C	2006	ALL	Body	Amplifier (Bose)																																																									
C	2006	ALL	Body	Body Control Module																																																									
C	2006	ALL	Body	CD Changer																																																									
C	2006	ALL	Body	Chime																																																									
C	2006	ALL	Body	Disc Player and Video Display																																																									
C	2006	ALL	Body	Driver Door Module																																																									
C	2006	ALL	Body	Driver Seat Module																			V																																							
C	2006	ALL	Body	Generator Battery Control Module																																																									
C	2006	ALL	Body	Heating and Air Conditioning Auto																			V																																							
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
C	2006	ALL	Body	Heating and Air Conditioning Manual																			V																																							
C	2006	ALL	Body	Instrument Panel Cluster																																																									
C	2006	ALL	Body	Passenger Door Module																																																									
C	2006	ALL	Body	Passenger Presence System																																																									
C	2006	ALL	Body	Base Radio																																																									
C	2006	ALL	Body	Uplevel Radio																																																									
C	2006	ALL	Body	Navigation Radio								V																																																
C	2006	ALL	Body	Rear Aux. Climate Module																																																									
C	2006	ALL	Body	Rear HVAC																																																									
C	2006	ALL	Body	Rear Seat Audio																																																									
C	2006	ALL	Body	Supplemental Inflatable Restraint	V																																																								
C	2006	ALL	Body	Vehicle Theft Deterrent		V																																																								
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																V	V	V							
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																				
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																				
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																				
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																				
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																				
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																				
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																				
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																V			
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																				
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																				
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES													V																																												
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
C	2007	Sierra	Chassis	Electronic Suspension Control																																																									
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																									
C	2007	Sierra	Body	Amplifier (Bose)																																																									
C	2007	Sierra	Body	Body Control Module			V																													V																										
C	2007	Sierra	Body	Body Control Module (aux.)																																																									
C	2007	Sierra	Body	Digital Radio Receiver																																																									
C	2007	Sierra	Body	Driver Door Switch																																																									
C	2007	Sierra	Body	HVAC Control Module Auto																																																									
C	2007	Sierra	Body	HVAC Control Module Manual																																																									
C	2007	Sierra	Body	Instrument Panel Cluster																																																									
C	2007	Sierra	Body	Memory Seat Module																					V	V																																			
C	2007	Sierra	Body	Park Assist Module																																																									
C	2007	Sierra	Body	Passenger Door Switch																																																									
C	2007	Sierra	Body	Passenger Presence System																																																									
C	2007	Sierra	Body	Radio																																																									
C	2007	Sierra	Body	Rear Heated Seat Module																																																									
C	2007	Sierra	Body	Rear HVAC/RSA																																																									
C	2007	Sierra	Body	Rollover Sensor																																																									
C	2007	Sierra	Body	Supplemental Inflatable Restraint																			V																																						
C	2007	Sierra	Body	Theft Deterrent Module		V																																																							
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																					
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES													V																																												
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
C	2007	Yukon	Chassis	Electronic Suspension Control																																																									
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																									
C	2007	Yukon	Body	Amplifier (Bose)																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2007	Yukon	Body	Assist Step Controller																																																								
C	2007	Yukon	Body	Body Control Module			V																													V																								
C	2007	Yukon	Body	Body Control Module (aux.)																																																								
C	2007	Yukon	Body	Digital Radio Receiver																																																								
C	2007	Yukon	Body	Driver Door Switch																																																								
C	2007	Yukon	Body	HVAC Control Module Auto																																																								
C	2007	Yukon	Body	HVAC Control Module Manual																																																								
C	2007	Yukon	Body	Instrument Panel Cluster																																																								
C	2007	Yukon	Body	Lift Gate Module																																																								
C	2007	Yukon	Body	Memory Seat Module																					V	V																																		
C	2007	Yukon	Body	Park Assist Module																																																								
C	2007	Yukon	Body	Passenger Door Switch																																																								
C	2007	Yukon	Body	Passenger Presence System																																																								
C	2007	Yukon	Body	Radio																																																								
C	2007	Yukon	Body	Rear Heated Seat Module																																																								
C	2007	Yukon	Body	Rear HVAC/RSA																																																								
C	2007	Yukon	Body	Rollover Sensor																																																								
C	2007	Yukon	Body	Supplemental Inflatable Restraint																			V																																					
C	2007	Yukon	Body	Theft Deterrent Module		V																																																						
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																			
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																			
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																			
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																			
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																			
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																			
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES													V																																											
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES													V																																											
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW													V																																											
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																								
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																								
C	2007	Yukon XL	Body	Amplifier (Bose)																																																								
C	2007	Yukon XL	Body	Assist Step Controller																																																								
C	2007	Yukon XL	Body	Body Control Module			V																													V																								
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																								
C	2007	Yukon XL	Body	Digital Radio Receiver																																																								
C	2007	Yukon XL	Body	Driver Door Switch																																																								
C	2007	Yukon XL	Body	HVAC Control Module Auto																																																								
C	2007	Yukon XL	Body	HVAC Control Module Manual																																																								
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																								
C	2007	Yukon XL	Body	Lift Gate Module																																																								
C	2007	Yukon XL	Body	Memory Seat Module																					V	V																																		
C	2007	Yukon XL	Body	Park Assist Module																																																								
C	2007	Yukon XL	Body	Passenger Door Switch																																																								
C	2007	Yukon XL	Body	Passenger Presence System																																																								
C	2007	Yukon XL	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2007	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2007	Yukon XL	Body	Rollover Sensor																																																										
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																			V																																							
C	2007	Yukon XL	Body	Theft Deterrent Module		V																																																									
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																						
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																						
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																						
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																						
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																						
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																						
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																						
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																					V		
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																						
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																						
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES													V																																														
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES													V																																														
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW													V																																														
C	2008	Sierra	Chassis	Electronic Suspension Control																																																											
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																											
C	2008	Sierra	Body	Amplifier (Bose)																																																											
C	2008	Sierra	Body	Body Control Module			V																													V																											
C	2008	Sierra	Body	Body Control Module (aux.)																																																											
C	2008	Sierra	Body	Digital Radio Receiver																																																											
C	2008	Sierra	Body	Driver Door Switch																																																											
C	2008	Sierra	Body	HVAC Control Module Auto																																																											
C	2008	Sierra	Body	HVAC Control Module Manual																																																											
C	2008	Sierra	Body	Instrument Panel Cluster																																																											
C	2008	Sierra	Body	Memory Seat Module																					V	V																																					
C	2008	Sierra	Body	Park Assist Module																																																											
C	2008	Sierra	Body	Passenger Door Switch																																																											
C	2008	Sierra	Body	Passenger Presence System																																																											
C	2008	Sierra	Body	Radio																																																											
C	2008	Sierra	Body	Rear Heated Seat Module																																																											
C	2008	Sierra	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2008	Sierra	Body	Rollover Sensor																																																								
C	2008	Sierra	Body	Supplemental Inflatable Restraint																			V																																					
C	2008	Sierra	Body	Theft Deterrent Module		V																																																						
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																			
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																			
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																			
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																			
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2008	Yukon	Chassis	Electronic Brake Control Module													V																																											
C	2008	Yukon	Chassis	Electronic Suspension Control																																																								
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																								
C	2008	Yukon	Body	Amplifier (Bose)																																																								
C	2008	Yukon	Body	Assist Step Controller																																																								
C	2008	Yukon	Body	Body Control Module			V																													V																								
C	2008	Yukon	Body	Body Control Module (aux.)																																																								
C	2008	Yukon	Body	Digital Radio Receiver																																																								
C	2008	Yukon	Body	Driver Door Switch																																																								
C	2008	Yukon	Body	HVAC Control Module Auto																																																								
C	2008	Yukon	Body	HVAC Control Module Manual																																																								
C	2008	Yukon	Body	Instrument Panel Cluster																																																								
C	2008	Yukon	Body	Lift Gate Module																																																								
C	2008	Yukon	Body	Memory Seat Module																					V	V																																		
C	2008	Yukon	Body	Park Assist Module																																																								
C	2008	Yukon	Body	Passenger Door Switch																																																								
C	2008	Yukon	Body	Passenger Presence System																																																								
C	2008	Yukon	Body	Radio																																																								
C	2008	Yukon	Body	Rear Heated Seat Module																																																								
C	2008	Yukon	Body	Rear HVAC/RSA																																																								
C	2008	Yukon	Body	Rollover Sensor																																																								
C	2008	Yukon	Body	Supplemental Inflatable Restraint																			V																																					
C	2008	Yukon	Body	Theft Deterrent Module		V																																																						
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V				
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																								
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																										
C	2008	Yukon Hybrid	Body	Body Control Module			V																													V																										
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																										
C	2008	Yukon Hybrid	Body	HVAC Control Module																																																										
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2008	Yukon Hybrid	Body	Lift Gate Module																																																										
C	2008	Yukon Hybrid	Body	Memory Seat Module																					V	V																																					
C	2008	Yukon Hybrid	Body	Park Assist Module																																																										
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																										
C	2008	Yukon Hybrid	Body	Passenger Presence System																																																										
C	2008	Yukon Hybrid	Body	Radio																																																										
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																										
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																			V																																							
C	2008	Yukon Hybrid	Body	Theft Deterrent Module		V																																																								
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																					
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																					
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon XL	Body	Amplifier (Bose)																																																										
C	2008	Yukon XL	Body	Assist Step Controller																																																										
C	2008	Yukon XL	Body	Body Control Module			V																													V																										
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2008	Yukon XL	Body	Digital Radio Receiver																																																										
C	2008	Yukon XL	Body	Driver Door Switch																																																										
C	2008	Yukon XL	Body	HVAC Control Module Auto																																																										
C	2008	Yukon XL	Body	HVAC Control Module Manual																																																										
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2008	Yukon XL	Body	Lift Gate Module																																																										
C	2008	Yukon XL	Body	Memory Seat Module																					V	V																																					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2008	Yukon XL	Body	Park Assist Module																																																										
C	2008	Yukon XL	Body	Passenger Door Switch																																																										
C	2008	Yukon XL	Body	Passenger Presence System																																																										
C	2008	Yukon XL	Body	Radio																																																										
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2008	Yukon XL	Body	Rollover Sensor																																																										
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																			V																																							
C	2008	Yukon XL	Body	Theft Deterrent Module		V																																																								
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																						
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																				V	
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																					
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual			V		V																																																				V	
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																				V	
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																					
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual			V		V																																																					
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES													V																																													
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES													V																																													
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																													
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																													
C	2009	Sierra	Chassis	Electronic Suspension Control																																																										
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																										
C	2009	Sierra	Body	Amplifier (Bose)																																																										
C	2009	Sierra	Body	Body Control Module			V																														V																									
C	2009	Sierra	Body	Body Control Module (aux.)																																																										
C	2009	Sierra	Body	Digital Radio Receiver																																																										
C	2009	Sierra	Body	Driver Door Switch																																																										
C	2009	Sierra	Body	HVAC Control Module Auto																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2009	Sierra	Body	HVAC Control Module Manual																																																									
C	2009	Sierra	Body	Instrument Panel Cluster																																																									
C	2009	Sierra	Body	Memory Seat Module																					V	V																																				
C	2009	Sierra	Body	Park Assist Module																																																								
C	2009	Sierra	Body	Passenger Door Switch																																																								
C	2009	Sierra	Body	Passenger Presence System																																																								
C	2009	Sierra	Body	Radio																																																								
C	2009	Sierra	Body	Rear Heated Seat Module																																																								
C	2009	Sierra	Body	Rear HVAC/RSA																																																								
C	2009	Sierra	Body	Rollover Sensor																																																								
C	2009	Sierra	Body	Supplemental Inflatable Restraint																			V																																						
C	2009	Sierra	Body	Theft Deterrent Module		V																																																							
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V				
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																								
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																								
C	2009	Sierra Hybrid	Body	Body Control Module			V																													V																									
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																								
C	2009	Sierra Hybrid	Body	Driver Door Switch																																																								
C	2009	Sierra Hybrid	Body	HVAC Control Module																																																								
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
C	2009	Sierra Hybrid	Body	Memory Seat Module																					V	V																																				
C	2009	Sierra Hybrid	Body	Park Assist Module																																																								
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																																								
C	2009	Sierra Hybrid	Body	Passenger Presence System																																																								
C	2009	Sierra Hybrid	Body	Radio																																																								
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																								
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																			V																																						
C	2009	Sierra Hybrid	Body	Theft Deterrent Module		V																																																							
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed			V		V																																																			
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed			V		V																																																			
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																								
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																			
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																				
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																				
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed			V		V																																																				
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed			V		V																																																				
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
C	2009	Yukon	Chassis	Electronic Brake Control Module													V																																												
C	2009	Yukon	Chassis	Electronic Suspension Control																																																										
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																										
C	2009	Yukon	Body	Amplifier (Bose)																																																										
C	2009	Yukon	Body	Assist Step Controller																																																										
C	2009	Yukon	Body	Body Control Module			V																													V																										
C	2009	Yukon	Body	Body Control Module (aux.)																																																										
C	2009	Yukon	Body	Digital Radio Receiver																																																										
C	2009	Yukon	Body	Driver Door Switch																																																										
C	2009	Yukon	Body	HVAC Control Module Auto																																																										
C	2009	Yukon	Body	HVAC Control Module Manual																																																										
C	2009	Yukon	Body	Instrument Panel Cluster																																																										
C	2009	Yukon	Body	Left Side Object Detection Module																																																										
C	2009	Yukon	Body	Lift Gate Module																																																										
C	2009	Yukon	Body	Memory Seat Module																					V	V																																				
C	2009	Yukon	Body	Park Assist Module																																																										
C	2009	Yukon	Body	Passenger Door Switch																																																										
C	2009	Yukon	Body	Passenger Presence System																																																										
C	2009	Yukon	Body	Radio																																																										
C	2009	Yukon	Body	Rear Heated Seat Module																																																										
C	2009	Yukon	Body	Rear HVAC/RSA																																																										
C	2009	Yukon	Body	Right Side Object Detection Module																																																										
C	2009	Yukon	Body	Rollover Sensor																																																										
C	2009	Yukon	Body	Supplemental Inflatable Restraint																			V																																							
C	2009	Yukon	Body	Theft Deterrent Module		V																																																								
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																V				
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																										
C	2009	Yukon Hybrid	Body	Body Control Module			V																													V																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																								
C	2009	Yukon Hybrid	Body	Driver Door Switch																																																								
C	2009	Yukon Hybrid	Body	Heated Seat Module																																																								
C	2009	Yukon Hybrid	Body	HVAC Control Module																																																								
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
C	2009	Yukon Hybrid	Body	Park Assist Module																																																								
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																																								
C	2009	Yukon Hybrid	Body	Passenger Presence System																																																								
C	2009	Yukon Hybrid	Body	Radio																																																								
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																								
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																			V																																					
C	2009	Yukon Hybrid	Body	Theft Deterrent Module		V																																																						
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																			
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																			
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																			
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																			
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																			
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																			
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW													V																																											
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW													V																																											
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																								
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																								
C	2009	Yukon XL	Body	Amplifier (Bose)																																																								
C	2009	Yukon XL	Body	Assist Step Controller																																																								
C	2009	Yukon XL	Body	Body Control Module			V																													V																								
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																								
C	2009	Yukon XL	Body	Digital Radio Receiver																																																								
C	2009	Yukon XL	Body	Driver Door Switch																																																								
C	2009	Yukon XL	Body	HVAC Control Module Auto																																																								
C	2009	Yukon XL	Body	HVAC Control Module Manual																																																								
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																								
C	2009	Yukon XL	Body	Left Side Object Detection Module																																																								
C	2009	Yukon XL	Body	Lift Gate Module																																																								
C	2009	Yukon XL	Body	Memory Seat Module																					V	V																																		

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2009	Yukon XL	Body	Park Assist Module																																																								
C	2009	Yukon XL	Body	Passenger Door Switch																																																								
C	2009	Yukon XL	Body	Passenger Presence System																																																								
C	2009	Yukon XL	Body	Radio																																																								
C	2009	Yukon XL	Body	Rear Heated Seat Module																																																								
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																								
C	2009	Yukon XL	Body	Right Side Object Detection Module																																																								
C	2009	Yukon XL	Body	Rollover Sensor																																																								
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																			V																																					
C	2009	Yukon XL	Body	Theft Deterrent Module		V																																																							
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																														V			V
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																													V			V
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual					V																																														V		
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																							
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																													V			
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																													V			
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																							
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																													V			
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																							
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																							
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																							
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																			
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																							
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																							
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																													V			
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																							
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																							
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																		
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																							
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES													V																																										
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES													V																																										
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																										
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																										
C	2010	Sierra	Chassis	Electronic Suspension Control																																																							
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																							
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																							
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																							
C	2010	Sierra	Body	Amplifier (Bose)																																																							
C	2010	Sierra	Body	Body Control Module			V																													V																								
C	2010	Sierra	Body	Body Control Module (aux.)																																																							
C	2010	Sierra	Body	Digital Radio Receiver																																																							
C	2010	Sierra	Body	Driver Door Switch																																																							
C	2010	Sierra	Body	HVAC Control Module Auto																																																							
C	2010	Sierra	Body	HVAC Control Module Manual																																																							
C	2010	Sierra	Body	Instrument Panel Cluster																																																							
C	2010	Sierra	Body	Memory Seat Module																					V	V																																		
C	2010	Sierra	Body	Park Assist Module																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2010	Sierra	Body	Passenger Door Switch																																																										
C	2010	Sierra	Body	Passenger Presence System																																																										
C	2010	Sierra	Body	Radio																																																										
C	2010	Sierra	Body	Rear Heated Seat Module																																																										
C	2010	Sierra	Body	Rear HVAC/RSA																																																										
C	2010	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2010	Sierra	Body	Theft Deterrent Module		V																																																								
C	2010	Sierra Hybrid	Powertrain	Engine Control Module					V																																																V				
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																									
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																									
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																									
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																									
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																									
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																									
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																									
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																									
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																									
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																									
C	2010	Sierra Hybrid	Body	Body Control Module			V																													V																										
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																									
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																									
C	2010	Sierra Hybrid	Body	Driver Door Switch																																																									
C	2010	Sierra Hybrid	Body	Heated Seat Module																																																									
C	2010	Sierra Hybrid	Body	HVAC Control Module																																																									
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																									
C	2010	Sierra Hybrid	Body	Park Assist Module																																																									
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																																									
C	2010	Sierra Hybrid	Body	Passenger Presence System																																																									
C	2010	Sierra Hybrid	Body	Radio																																																									
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																									
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																									
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																									
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																									
C	2010	Sierra Hybrid	Body	Theft Deterrent Module		V																																																								
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module			V		V																																																					
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Yukon	Chassis	Electronic Brake Control Module													V																																												
C	2010	Yukon	Chassis	Electronic Suspension Control																																																										
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon	Body	Amplifier (Bose)																																																									
C	2010	Yukon	Body	Assist Step Controller																																																									
C	2010	Yukon	Body	Body Control Module			V																													V																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2010	Yukon	Body	Body Control Module (aux.)																																																										
C	2010	Yukon	Body	Digital Radio Receiver																																																											
C	2010	Yukon	Body	Driver Door Switch																																																										
C	2010	Yukon	Body	HVAC Control Module Auto																																																										
C	2010	Yukon	Body	HVAC Control Module Manual																																																										
C	2010	Yukon	Body	Instrument Panel Cluster																																																										
C	2010	Yukon	Body	Left Side Object Detection Module																																																										
C	2010	Yukon	Body	Lift Gate Module																																																										
C	2010	Yukon	Body	Memory Seat Module																					V	V																																					
C	2010	Yukon	Body	Park Assist Module																																																										
C	2010	Yukon	Body	Passenger Door Switch																																																										
C	2010	Yukon	Body	Passenger Presence System																																																										
C	2010	Yukon	Body	Radio																																																										
C	2010	Yukon	Body	Rear Heated Seat Module																																																										
C	2010	Yukon	Body	Rear HVAC/RSA																																																										
C	2010	Yukon	Body	Right Side Object Detection Module																																																										
C	2010	Yukon	Body	Supplemental Inflatable Restraint																																																										
C	2010	Yukon	Body	Theft Deterrent Module		V																																																								
C	2010	Yukon Hybrid	Powertrain	Engine Control Module					V																																																V				
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																										
C	2010	Yukon Hybrid	Body	Body Control Module			V																													V																											
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2010	Yukon Hybrid	Body	Driver Door Switch																																																										
C	2010	Yukon Hybrid	Body	Heated Seat Module																																																										
C	2010	Yukon Hybrid	Body	HVAC Control Module																																																										
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
C	2010	Yukon Hybrid	Body	Lift Gate Module																																																										
C	2010	Yukon Hybrid	Body	Park Assist Module																																																										
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																																										
C	2010	Yukon Hybrid	Body	Passenger Presence System																																																										
C	2010	Yukon Hybrid	Body	Radio																																																										
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
C	2010	Yukon Hybrid	Body	Theft Deterrent Module		V																																																							
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V			
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module			V		V																																																			
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																			
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																V			
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																			
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW													V																																												
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW													V																																												
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																									
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																								
C	2010	Yukon XL	Body	Amplifier (Bose)																																																								
C	2010	Yukon XL	Body	Assist Step Controller																																																								
C	2010	Yukon XL	Body	Body Control Module			V																													V																									
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																								
C	2010	Yukon XL	Body	Digital Radio Receiver																																																								
C	2010	Yukon XL	Body	Driver Door Switch																																																								
C	2010	Yukon XL	Body	HVAC Control Module Auto																																																								
C	2010	Yukon XL	Body	HVAC Control Module Manual																																																								
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																								
C	2010	Yukon XL	Body	Left Side Object Detection Module																																																								
C	2010	Yukon XL	Body	Lift Gate Module																																																								
C	2010	Yukon XL	Body	Memory Seat Module																					V	V																																			
C	2010	Yukon XL	Body	Park Assist Module																																																								
C	2010	Yukon XL	Body	Passenger Door Switch																																																								
C	2010	Yukon XL	Body	Passenger Presence System																																																								
C	2010	Yukon XL	Body	Radio																																																								
C	2010	Yukon XL	Body	Rear Heated Seat Module																																																								
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																								
C	2010	Yukon XL	Body	Right Side Object Detection Module																																																								
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
C	2010	Yukon XL	Body	Theft Deterrent Module		V																																																							
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module			V		V																																																			
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																								
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																								
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module					V																																																			
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																								
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																								
D	2008	ALL	Chassis	Electronic Brake Control Module													V																																											
D	2008	ALL	Body	Body Control Module			V																													V																									
D	2008	ALL	Body	Body Control Module (aux.)																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
D	2008	ALL	Body	Headlamp Control Module																																																									
D	2008	ALL	Body	HVAC Control Module Auto																																																									
D	2008	ALL	Body	Instrument Panel Cluster																																																									
D	2008	ALL	Body	Park Assist Module																																																									
D	2008	ALL	Body	Remote Control Door Lock Receiver																																																									
D	2008	ALL	Body	Supplemental Inflatable Restraint																			V																																						
D	2008	ALL	Body	Theft Deterrent Module		V																																																								
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module			V		V																																																					
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module					V																																																					
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2009	ALL	Chassis	Electronic Brake Control Module													V																																												
D	2009	ALL	Body	Body Control Module			V																													V																											
D	2009	ALL	Body	Body Control Module (aux.)																																																										
D	2009	ALL	Body	Headlamp Control Module																																																										
D	2009	ALL	Body	HVAC Control Module Auto																																																										
D	2009	ALL	Body	Instrument Panel Cluster																																																										
D	2009	ALL	Body	Park Assist Module																																																										
D	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2009	ALL	Body	Supplemental Inflatable Restraint																			V																																						
D	2009	ALL	Body	Theft Deterrent Module		V																																																								
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module			V		V																																																					
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module					V																																															V			V
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module					V																																																					
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2010	ALL	Chassis	Electronic Brake Control Module													V																																												
D	2010	ALL	Body	Body Control Module			V																													V																											
D	2010	ALL	Body	Body Control Module (aux.)																																																										
D	2010	ALL	Body	Headlamp Control Module																																																										
D	2010	ALL	Body	HVAC Control Module Auto																																																										
D	2010	ALL	Body	Instrument Panel Cluster																																																										
D	2010	ALL	Body	Park Assist Module																																																										
D	2010	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2010	ALL	Body	Supplemental Inflatable Restraint																			V																																						
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM				V	V																																																					
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM				V	V																																																					
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module				V	V																																																					
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module				V	V																																																					
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																					
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																									
G	2004	Express/Savana	Body	Body Control Module																																																									
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2004	Express/Savana	Body	OnStar																																															V	V								
G	2004	Express/Savana	Body	Base Radio																																																									
G	2004	Express/Savana	Body	Uplevel Radio																																																									
G	2004	Express/Savana	Body	Remote Function Actuation																																																									
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM				V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM				V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																				
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module				V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																															V	V								
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control				V	V																																																					
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module			V	V	V																																																					
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																					
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																					
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																				
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2005	Express/Savana	Chassis	VSES																																																									
G	2005	Express/Savana	Body	Body Control Module																																																									
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2005	Express/Savana	Body	Base Radio																																																										
G	2005	Express/Savana	Body	Uplevel Radio																																																										
G	2005	Express/Savana	Body	Remote Function Actuation																																																										
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																V	V								
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																				
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control				V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module			V	V	V																																																				
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2005	Express Access/Savana Pro	Chassis	VSES																																																										
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2005	Express Access/Savana Pro	Body	Base Radio																																																										
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																V	V								
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control				V	V																																																					
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control			V	V	V																																																					
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																					
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																					
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																					
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																			
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																			
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2006	Express/Savana	Chassis	VSES																																																									
G	2006	Express/Savana	Body	Body Control Module																																																									
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2006	Express/Savana	Body	Passenger Presence System																																																									
G	2006	Express/Savana	Body	Base Radio																																																									
G	2006	Express/Savana	Body	Uplevel Radio																																																									
G	2006	Express/Savana	Body	Remote Function Actuation																																																									
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint	V																																																								
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																															V	V	V							
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																				
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control				V	V																																																				
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control			V	V	V																																																				
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																				
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																				
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																				
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																				
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																			
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2006	Express Access/Savana Pro	Chassis	VSES																																																									
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2006	Express Access/Savana Pro	Body	Base Radio																																																									
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V																																																								
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																															V	V	V							
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																				
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control				V	V																																																				
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control			V	V	V																																																				

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																			
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																			
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																			
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																			
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																			
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																			
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																		V	
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2007	Express/Savana	Body	Body Control Module																																																								
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2007	Express/Savana	Body	Passenger Presence System																																																								
G	2007	Express/Savana	Body	Base Radio																																																								
G	2007	Express/Savana	Body	Uplevel Radio																																																								
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint	V																																																							
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																	V	V	V					
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																			
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control				V	V																																																			
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control			V	V	V																																																			
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																			
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																			
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																			
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control				V	V																																																			
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control			V	V	V																																																			
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																			
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																		V	

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2007	Express Access/Savana Pro	Body	Radio																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V																																																								
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																															V	V	V							
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																				
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																					
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																															V					
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																													
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																													
G	2008	Express/Savana	Body	Body Control Module			V																																																							
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2008	Express/Savana	Body	Passenger Presence System																																																										
G	2008	Express/Savana	Body	Radio																																																									
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express/Savana	Body	Rollover Sensor																																																										
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																							
G	2008	Express/Savana	Body	Theft Deterrent Module		V																																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																					
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																					
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																														V					
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																													

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																												
G	2008	Express Access/Savana Pro	Body	Body Control Module			V																																																						
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2008	Express Access/Savana Pro	Body	Radio																																																									
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																						
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																								
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																					
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																					
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																														V			V
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																														V						
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																												
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																												
G	2009	Express/Savana	Body	Body Control Module			V																																																							
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2009	Express/Savana	Body	Passenger Presence System																																																										
G	2009	Express/Savana	Body	Radio																																																									
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2009	Express/Savana	Body	Rollover Sensor																																																									
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																						
G	2009	Express/Savana	Body	Theft Deterrent Module		V																																																								
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																					
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																					
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																														V			V
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																														V						
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																												
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																												
G	2009	Express Access/Savana Pro	Body	Body Control Module			V																																																							
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2009	Express Access/Savana Pro	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																					
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																						
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																														V			V
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																													V			
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																						
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																													V			
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																						
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																						
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																													V			
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																						
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																													V			
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																						
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																						
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																													V			
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																						
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																						
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																										
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																										
G	2010	Express/Savana	Body	Body Control Module			V																																																				
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2010	Express/Savana	Body	Passenger Presence System																																																						
G	2010	Express/Savana	Body	Radio																																																						
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
G	2010	Express/Savana	Body	Rollover Sensor																																																						
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																					
G	2010	Express/Savana	Body	Theft Deterrent Module		V																																																						
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																													V			V
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																													V			
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																						
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																													V			
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																						
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																													V			
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																						
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																													V			
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																						
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																						
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																													V			
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																						
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																						
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																										
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																										
G	2010	Express Access/Savana Pro	Body	Body Control Module			V																																																				

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2010	Express Access/Savana Pro	Body	Radio																																																								
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																					
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																						
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module				V	V																																																			
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2004	Express/Savana	Chassis	VSES																																																								
H	2004	Express/Savana	Body	Body Control Module																																																								
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2004	Express/Savana	Body	OnStar																																															V	V								
H	2004	Express/Savana	Body	Base Radio																																																								
H	2004	Express/Savana	Body	Uplevel Radio																																																								
H	2004	Express/Savana	Body	Remote Function Actuation																																																								
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module				V	V																																																			
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																								
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2004	Express Access/Savana Pro	Chassis	VSES																																																								
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2004	Express Access/Savana Pro	Body	OnStar																																															V	V								
H	2004	Express Access/Savana Pro	Body	Base Radio																																																								
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																			
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																			
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2005	Express/Savana	Chassis	VSES																																																								
H	2005	Express/Savana	Body	Body Control Module																																																								
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2005	Express/Savana	Body	Base Radio																																																								
H	2005	Express/Savana	Body	Uplevel Radio																																																								
H	2005	Express/Savana	Body	Remote Function Actuation																																																								
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																															V	V								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																			
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																			
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2005	Express Access/Savana Pro	Chassis	VSES																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2005	Express Access/Savana Pro	Body	Base Radio																																																								
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																															V	V								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																			
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																			
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2006	Express/Savana	Chassis	VSES																																																								
H	2006	Express/Savana	Body	Body Control Module																																																								
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2006	Express/Savana	Body	Passenger Presence System																																																								
H	2006	Express/Savana	Body	Base Radio																																																								
H	2006	Express/Savana	Body	Uplevel Radio																																																								
H	2006	Express/Savana	Body	Remote Function Actuation																																																								
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint	V																																																							
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																															V	V	V							
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																			
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																			
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2006	Express Access/Savana Pro	Chassis	VSES																																																								
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2006	Express Access/Savana Pro	Body	Base Radio																																																								
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V																																																							
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																															V	V	V							
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																			
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																			
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																			
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2007	Express/Savana	Body	Body Control Module																																																								
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2007	Express/Savana	Body	Passenger Presence System																																																								
H	2007	Express/Savana	Body	Base Radio																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2007	Express/Savana	Body	Uplevel Radio																																																								
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint	V																																																							
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																															V	V	V							
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																			
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control				V	V																																																			
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control			V	V	V																																																			
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2007	Express Access/Savana Pro	Body	Base Radio																																																								
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint	V																																																							
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																															V	V	V							
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																			
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																			
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																			
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																			
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																											
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																											
H	2008	Express/Savana	Body	Body Control Module			V																																																					
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2008	Express/Savana	Body	Passenger Presence System																																																								
H	2008	Express/Savana	Body	Radio																																																								
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2008	Express/Savana	Body	Rollover Sensor																																																								
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																					
H	2008	Express/Savana	Body	Theft Deterrent Module		V																																																						
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																			
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																			
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																			
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																			
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																											
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2008	Express Access/Savana Pro	Body	Body Control Module			V																																																					
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2008	Express Access/Savana Pro	Body	Radio																																																								
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																					
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																						
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																			
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																			
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																			
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																															V			V
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																										
H	2009	Express/Savana	Body	Body Control Module			V																																																					
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2009	Express/Savana	Body	Passenger Presence System																																																								
H	2009	Express/Savana	Body	Radio																																																								
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2009	Express/Savana	Body	Rollover Sensor																																																								
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																					
H	2009	Express/Savana	Body	Theft Deterrent Module		V																																																						
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																			
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																		
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module			V		V																																																			
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																															V			V
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module			V																																																					
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2009	Express Access/Savana Pro	Body	Radio																																																								
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																					
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																						
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V				
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																														V				
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																V			
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																										
H	2010	Express/Savana	Body	Body Control Module			V																																																					
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2010	Express/Savana	Body	Passenger Presence System																																																								
H	2010	Express/Savana	Body	Radio																																																								
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2010	Express/Savana	Body	Rollover Sensor																																																								
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																					
H	2010	Express/Savana	Body	Theft Deterrent Module		V																																																							
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																																V			
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V			
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V			
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																										
H	2010	Express Access/Savana Pro	Body	Body Control Module			V																																																					
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2010	Express Access/Savana Pro	Body	Radio																																																								
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																					
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																						
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM			V	V	V																																																			
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM			V	V	V																																																			
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM			V	V	V																																																			
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																			
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																			
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																				
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module			V	V	V																																																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module				V	V																																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module				V	V																																																				
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module					V																																																				
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																									
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																				
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module			V	V	V																																																				
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																									
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
K	2004	ALL	Chassis	ESC																																																								
K	2004	ALL	Chassis	Rear Wheel Steering																																																									
K	2004	ALL	Chassis	Tire Pressure Monitor																																																									
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																									
K	2004	ALL	Chassis	VSES																																																									
K	2004	ALL	Body	Amplifier (Bose)																																																									
K	2004	ALL	Body	Body Control Module																																																									
K	2004	ALL	Body	CD Changer																																																									
K	2004	ALL	Body	Chime																																																									
K	2004	ALL	Body	Driver Door Module																																																									
K	2004	ALL	Body	Driver Seat Module																			V																																						
K	2004	ALL	Body	Heating and Air Conditioning Auto																			V																																						
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																			V																																						
K	2004	ALL	Body	Instrument Panel Cluster																																																									
K	2004	ALL	Body	OnStar																																															V	V								
K	2004	ALL	Body	Passenger Door Module																																																									
K	2004	ALL	Body	Passenger Presence System																																																									
K	2004	ALL	Body	Radio Base																																																									
K	2004	ALL	Body	Radio Uplevel																																																									
K	2004	ALL	Body	Radio Navigation								V																																																
K	2004	ALL	Body	Rear Aux. Climate Module																																																									
K	2004	ALL	Body	Rear HVAC																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2004	ALL	Body	Rear Seat Audio																																																										
K	2004	ALL	Body	Rear Seat Entertainment																																																										
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2004	ALL	Body	Vehicle Theft Deterrent		V																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM			V	V	V																																																					
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM			V	V	V																																																					
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM			V	V	V																																																					
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																					
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module			V	V	V																																																					
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																					
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module			V	V	V																																																					
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module				V	V																																																					
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module				V	V																																																					
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module			V	V	V																																																					
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																			V																																								
K	2005	ALL	Body	Generator Battery Control Module																																																											
K	2005	ALL	Body	Heating and Air Conditioning Auto																			V																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2005	ALL	Body	Heating and Air Conditioning Manual																			V																																								
K	2005	ALL	Body	Instrument Panel Cluster																																																											
K	2005	ALL	Body	Passenger Door Module																																																											
K	2005	ALL	Body	Passenger Presence System																																																											
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio								V																																																		
K	2005	ALL	Body	Rear Aux. Climate Module																																																											
K	2005	ALL	Body	Rear HVAC																																																											
K	2005	ALL	Body	Rear Seat Audio																																																											
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																	V	V								
K	2005	ALL	Body	Vehicle Theft Deterrent		V																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM			V	V	V																																																						
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM			V	V	V																																																						
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM			V	V	V																																																						
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																						
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module			V	V	V																																																						
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module			V	V	V																																																						
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module			V	V	V																																																					
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																											
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module			V	V	V																																																						
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module				V	V																																																						
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																											
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module				V	V																																																						
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																											
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																											
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module					V																																																						
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																											
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																											
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																						
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module			V	V	V																																																						
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																											
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																											
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																											
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																											
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																											
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
K	2006	ALL	Chassis	ESC																																																										
K	2006	ALL	Chassis	Tire Pressure Monitor																																																											
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																											
K	2006	ALL	Chassis	VSES																																																										
K	2006	ALL	Body	Amplifier (Bose)																																																											
K	2006	ALL	Body	Body Control Module																																																										
K	2006	ALL	Body	CD Changer																																																										
K	2006	ALL	Body	Chime																																																										
K	2006	ALL	Body	Disc Player and Video Display																																																											
K	2006	ALL	Body	Driver Door Module																																																										
K	2006	ALL	Body	Driver Seat Module																			V																																							
K	2006	ALL	Body	Generator Battery Control Module																																																											
K	2006	ALL	Body	Heating and Air Conditioning Auto																			V																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																								
K	2006	ALL	Body	Heating and Air Conditioning Manual																			V																																						
K	2006	ALL	Body	Instrument Panel Cluster																																																									
K	2006	ALL	Body	Passenger Door Module																																																									
K	2006	ALL	Body	Passenger Presence System																																																									
K	2006	ALL	Body	Base Radio																																																									
K	2006	ALL	Body	Uplevel Radio																																																									
K	2006	ALL	Body	Navigation Radio								V																																																	
K	2006	ALL	Body	Rear Aux. Climate Module																																																										
K	2006	ALL	Body	Rear HVAC																																																										
K	2006	ALL	Body	Rear Seat Audio																																																										
K	2006	ALL	Body	Supplemental Inflatable Restraint	V																																																									
K	2006	ALL	Body	Vehicle Theft Deterrent		V																																																								
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																V	V	V							
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																				
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																					
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																					
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																					
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																															V					
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES													V																																													
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES													V																																													
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW													V																																													
K	2007	Sierra	Chassis	Electronic Suspension Control																																																											
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																											
K	2007	Sierra	Body	Amplifier (Bose)																																																											
K	2007	Sierra	Body	Body Control Module			V																													V																												
K	2007	Sierra	Body	Body Control Module (aux.)																																																											
K	2007	Sierra	Body	Digital Radio Receiver																																																											
K	2007	Sierra	Body	Driver Door Switch																																																											
K	2007	Sierra	Body	HVAC Control Module Auto																																																											
K	2007	Sierra	Body	HVAC Control Module Manual																																																											
K	2007	Sierra	Body	Instrument Panel Cluster																																																											
K	2007	Sierra	Body	Memory Seat Module																					V	V																																						
K	2007	Sierra	Body	Park Assist Module																																																											
K	2007	Sierra	Body	Passenger Door Switch																																																											
K	2007	Sierra	Body	Passenger Presence System																																																											
K	2007	Sierra	Body	Radio																																																											
K	2007	Sierra	Body	Rear Heated Seat Module																																																											
K	2007	Sierra	Body	Rear HVAC/RSA																																																											
K	2007	Sierra	Body	Rollover Sensor																																																											
K	2007	Sierra	Body	Supplemental Inflatable Restraint																			V																																								
K	2007	Sierra	Body	Theft Deterrent Module		V																																																										
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																						
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																						
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																											
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																						
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																						
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES													V																																														
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES													V																																														
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW													V																																														
K	2007	Yukon	Chassis	Electronic Suspension Control																																																											
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																											
K	2007	Yukon	Body	Amplifier (Bose)																																																											
K	2007	Yukon	Body	Assist Step Controller																																																											
K	2007	Yukon	Body	Body Control Module			V																													V																												
K	2007	Yukon	Body	Body Control Module (aux.)																																																											
K	2007	Yukon	Body	Digital Radio Receiver																																																											
K	2007	Yukon	Body	Driver Door Switch																																																											
K	2007	Yukon	Body	HVAC Control Module Auto																																																											
K	2007	Yukon	Body	HVAC Control Module Manual																																																											
K	2007	Yukon	Body	Instrument Panel Cluster																																																											
K	2007	Yukon	Body	Lift Gate Module																																																											
K	2007	Yukon	Body	Memory Seat Module																					V	V																																						
K	2007	Yukon	Body	Park Assist Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2007	Yukon	Body	Passenger Door Switch																																																								
K	2007	Yukon	Body	Passenger Presence System																																																								
K	2007	Yukon	Body	Radio																																																								
K	2007	Yukon	Body	Rear Heated Seat Module																																																								
K	2007	Yukon	Body	Rear HVAC/RSA																																																								
K	2007	Yukon	Body	Rollover Sensor																																																								
K	2007	Yukon	Body	Supplemental Inflatable Restraint																			V																																					
K	2007	Yukon	Body	Theft Deterrent Module		V																																																						
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																			
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																			
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																			
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																			
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																			
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																			
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES													V																																											
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES													V																																											
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW													V																																											
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																								
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																								
K	2007	Yukon XL	Body	Amplifier (Bose)																																																								
K	2007	Yukon XL	Body	Assist Step Controller																																																								
K	2007	Yukon XL	Body	Body Control Module			V																													V																								
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																								
K	2007	Yukon XL	Body	Digital Radio Receiver																																																								
K	2007	Yukon XL	Body	Driver Door Switch																																																								
K	2007	Yukon XL	Body	HVAC Control Module Auto																																																								
K	2007	Yukon XL	Body	HVAC Control Module Manual																																																								
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																								
K	2007	Yukon XL	Body	Lift Gate Module																																																								
K	2007	Yukon XL	Body	Memory Seat Module																					V	V																																		
K	2007	Yukon XL	Body	Park Assist Module																																																								
K	2007	Yukon XL	Body	Passenger Door Switch																																																								
K	2007	Yukon XL	Body	Passenger Presence System																																																								
K	2007	Yukon XL	Body	Radio																																																								
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																								
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																								
K	2007	Yukon XL	Body	Rollover Sensor																																																								
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																			V																																					
K	2007	Yukon XL	Body	Theft Deterrent Module		V																																																						
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																			

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																				
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																				
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																				
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																				
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																				
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																				
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																			V		
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																				
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																				
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES													V																																												
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES													V																																												
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
K	2008	Sierra	Chassis	Electronic Suspension Control																																																									
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																									
K	2008	Sierra	Body	Amplifier (Bose)																																																									
K	2008	Sierra	Body	Body Control Module			V																													V																									
K	2008	Sierra	Body	Body Control Module (aux.)																																																									
K	2008	Sierra	Body	Digital Radio Receiver																																																									
K	2008	Sierra	Body	Driver Door Switch																																																									
K	2008	Sierra	Body	HVAC Control Module Auto																																																									
K	2008	Sierra	Body	HVAC Control Module Manual																																																									
K	2008	Sierra	Body	Instrument Panel Cluster																																																									
K	2008	Sierra	Body	Memory Seat Module																					V	V																																			
K	2008	Sierra	Body	Park Assist Module																																																									
K	2008	Sierra	Body	Passenger Door Switch																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2008	Sierra	Body	Passenger Presence System																																																										
K	2008	Sierra	Body	Radio																																																										
K	2008	Sierra	Body	Rear Heated Seat Module																																																										
K	2008	Sierra	Body	Rear HVAC/RSA																																																										
K	2008	Sierra	Body	Rollover Sensor																																																										
K	2008	Sierra	Body	Supplemental Inflatable Restraint																			V																																							
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																										
K	2008	Sierra	Body	Theft Deterrent Module		V																																																								
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																					
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																					
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																					
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Yukon	Chassis	Electronic Brake Control Module													V																																													
K	2008	Yukon	Chassis	Electronic Suspension Control																																																										
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																										
K	2008	Yukon	Body	Amplifier (Bose)																																																										
K	2008	Yukon	Body	Assist Step Controller																																																										
K	2008	Yukon	Body	Body Control Module			V																														V																									
K	2008	Yukon	Body	Body Control Module (aux.)																																																										
K	2008	Yukon	Body	Digital Radio Receiver																																																										
K	2008	Yukon	Body	Driver Door Switch																																																										
K	2008	Yukon	Body	HVAC Control Module Auto																																																										
K	2008	Yukon	Body	HVAC Control Module Manual																																																										
K	2008	Yukon	Body	Instrument Panel Cluster																																																										
K	2008	Yukon	Body	Lift Gate Module																																																										
K	2008	Yukon	Body	Memory Seat Module																					V	V																																				
K	2008	Yukon	Body	Park Assist Module																																																										
K	2008	Yukon	Body	Passenger Door Switch																																																										
K	2008	Yukon	Body	Passenger Presence System																																																										
K	2008	Yukon	Body	Radio																																																										
K	2008	Yukon	Body	Rear Heated Seat Module																																																										
K	2008	Yukon	Body	Rear HVAC/RSA																																																										
K	2008	Yukon	Body	Rollover Sensor																																																										
K	2008	Yukon	Body	Supplemental Inflatable Restraint																			V																																							
K	2008	Yukon	Body	Theft Deterrent Module		V																																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																V					
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																								
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																								
K	2008	Yukon Hybrid	Body	Body Control Module			V																		V																																				
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																								
K	2008	Yukon Hybrid	Body	Driver Door Switch																																																								
K	2008	Yukon Hybrid	Body	HVAC Control Module																																																								
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
K	2008	Yukon Hybrid	Body	Lift Gate Module																																																								
K	2008	Yukon Hybrid	Body	Memory Seat Module																					V	V																																			
K	2008	Yukon Hybrid	Body	Park Assist Module																																																								
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																																								
K	2008	Yukon Hybrid	Body	Passenger Presence System																																																								
K	2008	Yukon Hybrid	Body	Radio																																																								
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																								
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																			V																																					
K	2008	Yukon Hybrid	Body	Theft Deterrent Module		V																																																						
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																			
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																		
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																		
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module			V		V																																																		
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																		
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																			
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																								
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW													V																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																								
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																								
K	2008	Yukon XL	Body	Amplifier (Bose)																																																								
K	2008	Yukon XL	Body	Assist Step Controller																																																								
K	2008	Yukon XL	Body	Body Control Module			V																														V																							
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																								
K	2008	Yukon XL	Body	Digital Radio Receiver																																																								
K	2008	Yukon XL	Body	Driver Door Switch																																																								
K	2008	Yukon XL	Body	HVAC Control Module Auto																																																								
K	2008	Yukon XL	Body	HVAC Control Module Manual																																																								
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																								
K	2008	Yukon XL	Body	Lift Gate Module																																																								
K	2008	Yukon XL	Body	Memory Seat Module																					V	V																																		
K	2008	Yukon XL	Body	Park Assist Module																																																								
K	2008	Yukon XL	Body	Passenger Door Switch																																																								
K	2008	Yukon XL	Body	Passenger Presence System																																																								
K	2008	Yukon XL	Body	Radio																																																								
K	2008	Yukon XL	Body	Rear Heated Seat Module																																																								
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																								
K	2008	Yukon XL	Body	Rollover Sensor																																																								
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																			V																																					
K	2008	Yukon XL	Body	Theft Deterrent Module		V																																																						
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																			
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module			V		V																																																V			
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																			
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto			V		V																																																			
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul			V		V																																																	V		
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																			
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																								
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																			
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																V			
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																					
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES													V																																												
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES													V																																												
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																												
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																												
K	2009	Sierra	Chassis	Electronic Suspension Control																																																										
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2009	Sierra	Body	Amplifier (Bose)																																																										
K	2009	Sierra	Body	Body Control Module			V																													V																										
K	2009	Sierra	Body	Body Control Module (aux.)																																																										
K	2009	Sierra	Body	Digital Radio Receiver																																																										
K	2009	Sierra	Body	Driver Door Switch																																																										
K	2009	Sierra	Body	HVAC Control Module Auto																																																										
K	2009	Sierra	Body	HVAC Control Module Manual																																																										
K	2009	Sierra	Body	Instrument Panel Cluster																																																										
K	2009	Sierra	Body	Memory Seat Module																					V	V																																				
K	2009	Sierra	Body	Park Assist Module																																																										
K	2009	Sierra	Body	Passenger Door Switch																																																										
K	2009	Sierra	Body	Passenger Presence System																																																										
K	2009	Sierra	Body	Radio																																																										
K	2009	Sierra	Body	Rear Heated Seat Module																																																										
K	2009	Sierra	Body	Rear HVAC/RSA																																																										
K	2009	Sierra	Body	Rollover Sensor																																																										
K	2009	Sierra	Body	Supplemental Inflatable Restraint																			V																																							
K	2009	Sierra	Body	Theft Deterrent Module		V																																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V				
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																								
K	2009	Sierra Hybrid	Body	Body Control Module			V																													V																								
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																								
K	2009	Sierra Hybrid	Body	Driver Door Switch																																																								
K	2009	Sierra Hybrid	Body	HVAC Control Module																																																								
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
K	2009	Sierra Hybrid	Body	Memory Seat Module																					V	V																																			
K	2009	Sierra Hybrid	Body	Park Assist Module																																																								
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																																								
K	2009	Sierra Hybrid	Body	Passenger Presence System																																																								
K	2009	Sierra Hybrid	Body	Radio																																																								
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
K	2009	Sierra Hybrid	Body	Rollover Sensor																																																								
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																			V																																					
K	2009	Sierra Hybrid	Body	Theft Deterrent Module		V																																																							
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																				
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																								
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																								
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module			V		V																																																			
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																			
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																			
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																			
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																								
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																								
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2009	Yukon	Chassis	Electronic Brake Control Module													V																																											
K	2009	Yukon	Chassis	Electronic Suspension Control																																																								
K	2009	Yukon	Chassis	Trailer Brake Control Module																																																								
K	2009	Yukon	Body	Amplifier (Bose)																																																								
K	2009	Yukon	Body	Assist Step Controller																																																								
K	2009	Yukon	Body	Body Control Module			V																													V																								
K	2009	Yukon	Body	Body Control Module (aux.)																																																								
K	2009	Yukon	Body	Digital Radio Receiver																																																								
K	2009	Yukon	Body	Driver Door Switch																																																								
K	2009	Yukon	Body	HVAC Control Module Auto																																																								
K	2009	Yukon	Body	HVAC Control Module Manual																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2009	Yukon	Body	Instrument Panel Cluster																																																								
K	2009	Yukon	Body	Left Side Object Detection Module																																																								
K	2009	Yukon	Body	Lift Gate Module																																																								
K	2009	Yukon	Body	Memory Seat Module																					V	V																																		
K	2009	Yukon	Body	Park Assist Module																																																								
K	2009	Yukon	Body	Passenger Door Switch																																																								
K	2009	Yukon	Body	Passenger Presence System																																																								
K	2009	Yukon	Body	Radio																																																								
K	2009	Yukon	Body	Rear Heated Seat Module																																																								
K	2009	Yukon	Body	Rear HVAC/RSA																																																								
K	2009	Yukon	Body	Right Side Object Detection Module																																																								
K	2009	Yukon	Body	Rollover Sensor																																																								
K	2009	Yukon	Body	Supplemental Inflatable Restraint																			V																																					
K	2009	Yukon	Body	Theft Deterrent Module		V																																																						
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																															V				
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																								
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																								
K	2009	Yukon Hybrid	Body	Body Control Module			V																													V																								
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																								
K	2009	Yukon Hybrid	Body	Driver Door Switch																																																								
K	2009	Yukon Hybrid	Body	Heated Seat Module																																																								
K	2009	Yukon Hybrid	Body	HVAC Control Module																																																								
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
K	2009	Yukon Hybrid	Body	Park Assist Module																																																								
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																																								
K	2009	Yukon Hybrid	Body	Passenger Presence System																																																								
K	2009	Yukon Hybrid	Body	Radio																																																								
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
K	2009	Yukon Hybrid	Body	Rollover Sensor																																																								
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																			V																																					
K	2009	Yukon Hybrid	Body	Theft Deterrent Module		V																																																						
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module			V		V																																																				
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module			V		V																																																					
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module			V		V																																																						
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																						
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module			V		V																																																						
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																						
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW													V																																													
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW													V																																													
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																											
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																											
K	2009	Yukon XL	Body	Amplifier (Bose)																																																											
K	2009	Yukon XL	Body	Assist Step Controller																																																											
K	2009	Yukon XL	Body	Body Control Module			V																													V																											
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																											
K	2009	Yukon XL	Body	Digital Radio Receiver																																																											
K	2009	Yukon XL	Body	Driver Door Switch																																																											
K	2009	Yukon XL	Body	HVAC Control Module Auto																																																											
K	2009	Yukon XL	Body	HVAC Control Module Manual																																																											
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																											
K	2009	Yukon XL	Body	Left Side Object Detection Module																																																											
K	2009	Yukon XL	Body	Lift Gate Module																																																											
K	2009	Yukon XL	Body	Memory Seat Module																					V	V																																					
K	2009	Yukon XL	Body	Park Assist Module																																																											
K	2009	Yukon XL	Body	Passenger Door Switch																																																											
K	2009	Yukon XL	Body	Passenger Presence System																																																											
K	2009	Yukon XL	Body	Radio																																																											
K	2009	Yukon XL	Body	Rear Heated Seat Module																																																											
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																											
K	2009	Yukon XL	Body	Right Side Object Detection Module																																																											
K	2009	Yukon XL	Body	Rollover Sensor																																																											
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																			V																																							
K	2009	Yukon XL	Body	Theft Deterrent Module		V																																																									
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V			V
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto					V																																														V			V
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual					V																																															V			

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																	V			
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																																	V			
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module					V																																																	V			
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																					
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																	V			
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																					
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES													V																																												
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES													V																																												
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																												
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																												
K	2010	Sierra	Chassis	Electronic Suspension Control																																																										
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra	Body	Amplifier (Bose)																																																										
K	2010	Sierra	Body	Body Control Module			V																													V																										
K	2010	Sierra	Body	Body Control Module (aux.)																																																										
K	2010	Sierra	Body	Digital Radio Receiver																																																										
K	2010	Sierra	Body	Driver Door Switch																																																										
K	2010	Sierra	Body	HVAC Control Module Auto																																																										
K	2010	Sierra	Body	HVAC Control Module Manual																																																										
K	2010	Sierra	Body	Instrument Panel Cluster																																																										
K	2010	Sierra	Body	Memory Seat Module																					V	V																																				
K	2010	Sierra	Body	Park Assist Module																																																										
K	2010	Sierra	Body	Passenger Door Switch																																																										
K	2010	Sierra	Body	Passenger Presence System																																																										
K	2010	Sierra	Body	Radio																																																										
K	2010	Sierra	Body	Rear Heated Seat Module																																																										
K	2010	Sierra	Body	Rear HVAC/RSA																																																										
K	2010	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2010	Sierra	Body	Theft Deterrent Module		V																																																								
K	2010	Sierra Hybrid	Powertrain	Engine Control Module					V																																																	V			
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Sierra Hybrid	Body	Body Control Module			V																													V																											
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Sierra Hybrid	Body	Driver Door Switch																																																										
K	2010	Sierra Hybrid	Body	Heated Seat Module																																																										
K	2010	Sierra Hybrid	Body	HVAC Control Module																																																										
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Sierra Hybrid	Body	Park Assist Module																																																										
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																																										
K	2010	Sierra Hybrid	Body	Passenger Presence System																																																										
K	2010	Sierra Hybrid	Body	Radio																																																										
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2010	Sierra Hybrid	Body	Theft Deterrent Module		V																																																								
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module			V		V																																																					
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module			V		V																																																				
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon	Chassis	Electronic Brake Control Module													V																																													
K	2010	Yukon	Chassis	Electronic Suspension Control																																																											
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon	Body	Amplifier (Bose)																																																										
K	2010	Yukon	Body	Assist Step Controller																																																										
K	2010	Yukon	Body	Body Control Module			V																													V																											
K	2010	Yukon	Body	Body Control Module (aux.)																																																										
K	2010	Yukon	Body	Digital Radio Receiver																																																										
K	2010	Yukon	Body	Driver Door Switch																																																										
K	2010	Yukon	Body	HVAC Control Module Auto																																																										
K	2010	Yukon	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2010	Yukon	Body	Instrument Panel Cluster																																																								
K	2010	Yukon	Body	Left Side Object Detection Module																																																								
K	2010	Yukon	Body	Lift Gate Module																																																								
K	2010	Yukon	Body	Memory Seat Module																					V	V																																		
K	2010	Yukon	Body	Park Assist Module																																																								
K	2010	Yukon	Body	Passenger Door Switch																																																								
K	2010	Yukon	Body	Passenger Presence System																																																								
K	2010	Yukon	Body	Radio																																																								
K	2010	Yukon	Body	Rear Heated Seat Module																																																								
K	2010	Yukon	Body	Rear HVAC/RSA																																																								
K	2010	Yukon	Body	Right Side Object Detection Module																																																								
K	2010	Yukon	Body	Supplemental Inflatable Restraint																																																								
K	2010	Yukon	Body	Theft Deterrent Module		V																																																						
K	2010	Yukon Hybrid	Powertrain	Engine Control Module					V																																																V			
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																								
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																								
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																								
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																								
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																								
K	2010	Yukon Hybrid	Body	Body Control Module			V																													V																								
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																								
K	2010	Yukon Hybrid	Body	Driver Door Switch																																																								
K	2010	Yukon Hybrid	Body	Heated Seat Module																																																								
K	2010	Yukon Hybrid	Body	HVAC Control Module																																																								
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
K	2010	Yukon Hybrid	Body	Lift Gate Module																																																								
K	2010	Yukon Hybrid	Body	Park Assist Module																																																								
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																																								
K	2010	Yukon Hybrid	Body	Passenger Presence System																																																								
K	2010	Yukon Hybrid	Body	Radio																																																								
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2010	Yukon Hybrid	Body	Theft Deterrent Module		V																																																						
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																V			
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module			V		V																																																			
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module			V		V																																																			
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																														V			
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																														V			
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW													V																																											
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW													V																																											
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																								
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																								
K	2010	Yukon XL	Body	Amplifier (Bose)																																																								
K	2010	Yukon XL	Body	Assist Step Controller																																																								
K	2010	Yukon XL	Body	Body Control Module			V																													V																								
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																								
K	2010	Yukon XL	Body	Digital Radio Receiver																																																								
K	2010	Yukon XL	Body	Driver Door Switch																																																								
K	2010	Yukon XL	Body	HVAC Control Module Auto																																																								
K	2010	Yukon XL	Body	HVAC Control Module Manual																																																								
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																								
K	2010	Yukon XL	Body	Left Side Object Detection Module																																																								
K	2010	Yukon XL	Body	Lift Gate Module																																																								
K	2010	Yukon XL	Body	Memory Seat Module																					V	V																																		
K	2010	Yukon XL	Body	Park Assist Module																																																								
K	2010	Yukon XL	Body	Passenger Door Switch																																																								
K	2010	Yukon XL	Body	Passenger Presence System																																																								
K	2010	Yukon XL	Body	Radio																																																								
K	2010	Yukon XL	Body	Rear Heated Seat Module																																																								
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																								
K	2010	Yukon XL	Body	Right Side Object Detection Module																																																								
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
K	2010	Yukon XL	Body	Theft Deterrent Module		V																																																						
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																			
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
L	2004	ALL	Chassis	4WAL 3 Sensor																																																								
L	2004	ALL	Body	Body Control Module																												V																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2004	ALL	Body	Instrument Panel Cluster																																																								
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																			
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
L	2005	ALL	Chassis	4WAL 3 Sensor																																																								
L	2005	ALL	Body	Body Control Module																												V																												
L	2005	ALL	Body	Instrument Panel Cluster																																																								
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																								
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																								
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																								
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																								
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																								
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																								
L	2010	Terrain	Chassis	Electronic Brake Control Module																																																								
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2010	Terrain	Body	Body Control Module																																																								
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2010	Terrain	Body	Passenger Presence Module																																																								
L	2010	Terrain	Body	Instrument Cluster																																																								
L	2010	Terrain	Body	Radio																																																								
L	2010	Terrain	Body	Multimedia Player Interface Module																																																								
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																																								
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																																								
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																																								
L	2010	Terrain	Body	Liftgate Control Module																																																								
L	2010	Terrain	Body	Parking Assist Control Module																																																								
L	2010	Terrain	Body	Frontview Camera Module																																																								
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																																								
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																																								
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																								
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																								
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																								
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																								
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																								
L	2011	Terrain	Chassis	Electronic Brake Control Module																																																								
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2011	Terrain	Body	Body Control Module																																																								
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2011	Terrain	Body	Passenger Presence Module																																																								
L	2011	Terrain	Body	Instrument Cluster																																																								
L	2011	Terrain	Body	Radio																																																								
L	2011	Terrain	Body	Multimedia Player Interface Module																																																								
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2011	Terrain	Body	Liftgate Control Module																																																												
L	2011	Terrain	Body	Parking Assist Control Module																																																												
L	2011	Terrain	Body	Frontview Camera Module																																																												
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																												
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2012	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2012	Terrain	Body	Body Control Module																																																												
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2012	Terrain	Body	Passenger Presence Module																																																												
L	2012	Terrain	Body	Instrument Cluster																																																												
L	2012	Terrain	Body	Radio																																																												
L	2012	Terrain	Body	Multimedia Player Interface Module																																																												
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2012	Terrain	Body	Liftgate Control Module																																																												
L	2012	Terrain	Body	Parking Assist Control Module																																																												
L	2012	Terrain	Body	Frontview Camera Module																																																												
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																																												
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2013	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2013	Terrain	Chassis	Power Steering Control Module																																																												
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																																												
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2013	Terrain	Body	Passenger Presence Module																																																												
L	2013	Terrain	Body	Instrument Cluster																																																												
L	2013	Terrain	Body	Radio																																																												
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2013	Terrain	Body	Liftgate Control Module																																																												
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																												
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																												
L	2013	Terrain	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2013	Terrain	Body	Frontview Camera Module																																																										
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2014	Terrain	Chassis	Power Steering Control Module																																																										
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																																										
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Terrain	Body	Passenger Presence Module																																																										
L	2014	Terrain	Body	Instrument Cluster																																																										
L	2014	Terrain	Body	Radio																																																										
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2014	Terrain	Body	Liftgate Control Module																																																										
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																										
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																										
L	2014	Terrain	Body	Parking Assist Control Module																																																										
L	2014	Terrain	Body	Frontview Camera Module																																																										
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2015	Terrain	Chassis	Power Steering Control Module																																																										
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																																										
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Terrain	Body	Passenger Presence Module																																																										
L	2015	Terrain	Body	Instrument Cluster																																																										
L	2015	Terrain	Body	Radio																																																										
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																																										
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2015	Terrain	Body	Liftgate Control Module																																																										
L	2015	Terrain	Body	Seat Memory Control Module																																																										
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																										
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																										
L	2015	Terrain	Body	Parking Assist Control Module																																																										
L	2015	Terrain	Body	Frontview Camera Module																																																										
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																									
L	2016	Terrain	Chassis	Electronic Brake Control Module																																																									
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2016	Terrain	Chassis	Power Steering Control Module																																																									
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																																									
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																									
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2016	Terrain	Body	Passenger Presence Module																																																									
L	2016	Terrain	Body	Instrument Cluster																																																									
L	2016	Terrain	Body	Radio																																																									
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																																									
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																									
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																																									
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																																									
L	2016	Terrain	Body	Liftgate Control Module																																																									
L	2016	Terrain	Body	Seat Memory Control Module																																																									
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																									
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																									
L	2016	Terrain	Body	Parking Assist Control Module																																																									
L	2016	Terrain	Body	Frontview Camera Module																																																									
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																				
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
M	2004	ALL	Chassis	4WAL 3 Sensor																																																									
M	2004	ALL	Body	Body Control Module																												V																													
M	2004	ALL	Body	Instrument Panel Cluster																																																									
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																			
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
M	2005	ALL	Chassis	4WAL 3 Sensor																																																									
M	2005	ALL	Body	Body Control Module																												V																													
M	2005	ALL	Body	Instrument Panel Cluster																																																									
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module					V																																																				
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module					V																																																				
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module					V																																																				
P	2007	ALL	Body	Supplemental Inflatable Restraint	V																																																								
P	2007	ALL	Body	Theft Deterrent Module		V																																																							
R	2007	ALL	Powertrain	Engine Control Module					V																																																V			V
R	2007	ALL	Powertrain	Transmission Control Module																																																									
R	2007	ALL	Chassis	Electronic Brake Control Module													V																																												
R	2007	ALL	Body	Body Control Module			V																												V																										
R	2007	ALL	Body	Digital Radio Receiver																																																									
R	2007	ALL	Body	Driver Door Switch																																																									
R	2007	ALL	Body	Head Up Display																																																									
R	2007	ALL	Body	Heated Seat Module																																																									
R	2007	ALL	Body	HVAC Control Module Auto																																																									
R	2007	ALL	Body	HVAC Control Module Manual																																																									
R	2007	ALL	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2007	ALL	Body	Lift Gate Module																																																								
R	2007	ALL	Body	Park Assist Module																																																								
R	2007	ALL	Body	Passenger Door Switch																																																								
R	2007	ALL	Body	Passenger Presence System																																																								
R	2007	ALL	Body	Radio																																																								
R	2007	ALL	Body	Rear HVAC/RSA																																																								
R	2007	ALL	Body	Rollover Sensor																																																								
R	2007	ALL	Body	Supplemental Inflatable Restraint																			V																																						
R	2007	ALL	Body	Theft Deterrent Module		V																																																							
R	2008	ALL	Powertrain	Engine Control Module					V																																															V			V
R	2008	ALL	Powertrain	Transmission Control Module																																																								
R	2008	ALL	Chassis	Electronic Brake Control Module													V																																											
R	2008	ALL	Body	Body Control Module			V																													V																									
R	2008	ALL	Body	Digital Radio Receiver																																																								
R	2008	ALL	Body	Driver Door Switch																																																								
R	2008	ALL	Body	Head Up Display																																																								
R	2008	ALL	Body	Heated Seat Module																																																								
R	2008	ALL	Body	HVAC Control Module Auto																																																								
R	2008	ALL	Body	HVAC Control Module Manual																																																								
R	2008	ALL	Body	Instrument Panel Cluster																																																								
R	2008	ALL	Body	Lift Gate Module																																																								
R	2008	ALL	Body	Park Assist Module																																																								
R	2008	ALL	Body	Passenger Door Switch																																																								
R	2008	ALL	Body	Passenger Presence System																																																								
R	2008	ALL	Body	Radio																																																								
R	2008	ALL	Body	Rear HVAC/RSA																																																								
R	2008	ALL	Body	Rollover Sensor																																																								
R	2008	ALL	Body	Supplemental Inflatable Restraint																			V																																						
R	2008	ALL	Body	Theft Deterrent Module		V																																																							
R	2009	ALL	Powertrain	Engine Control Module					V																																															V			V
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2009	ALL	Powertrain	Transmission Control Module																																																								
R	2009	ALL	Chassis	Electronic Brake Control Module													V																																											
R	2009	ALL	Body	Body Control Module			V																													V																									
R	2009	ALL	Body	Digital Radio Receiver																																																								
R	2009	ALL	Body	Driver Door Switch																																																								
R	2009	ALL	Body	Head Up Display																																																								
R	2009	ALL	Body	Heated Seat Module																																																								
R	2009	ALL	Body	HVAC Control Module Auto																																																								
R	2009	ALL	Body	HVAC Control Module Manual																																																								
R	2009	ALL	Body	Instrument Panel Cluster																																																								
R	2009	ALL	Body	Lift Gate Module																																																								
R	2009	ALL	Body	Park Assist Module																																																								
R	2009	ALL	Body	Passenger Door Switch																																																								
R	2009	ALL	Body	Passenger Presence System																																																								
R	2009	ALL	Body	Radio																																																								
R	2009	ALL	Body	Rear HVAC/RSA																																																								
R	2009	ALL	Body	Rollover Sensor																																																								
R	2009	ALL	Body	Supplemental Inflatable Restraint																			V																																						
R	2009	ALL	Body	Theft Deterrent Module		V																																																							
R	2010	ALL	Powertrain	Engine Control Module					V																																																			V

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2010	ALL	Powertrain	Transmission Control Module																																																									
R	2010	ALL	Chassis	Electronic Brake Control Module													V																																											
R	2010	ALL	Body	Body Control Module			V																												V			V																							
R	2010	ALL	Body	Digital Radio Receiver																																																								
R	2010	ALL	Body	Driver Door Switch																																																								
R	2010	ALL	Body	Head Up Display																																																								
R	2010	ALL	Body	Heated Seat Module																																																								
R	2010	ALL	Body	HVAC Control Module Auto																																																								
R	2010	ALL	Body	HVAC Control Module Manual																																																								
R	2010	ALL	Body	Instrument Panel Cluster																																																								
R	2010	ALL	Body	Lift Gate Module																																																								
R	2010	ALL	Body	Park Assist Module																																																								
R	2010	ALL	Body	Passenger Door Switch																																																								
R	2010	ALL	Body	Passenger Presence System																																																								
R	2010	ALL	Body	Radio																																																								
R	2010	ALL	Body	Rear HVAC/RSA																																																								
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2010	ALL	Body	Theft Deterrent Module		V																																																						
R	2011	ALL	Powertrain	Engine Control Module					V																																																				V
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2011	ALL	Powertrain	Transmission Control Module																																																								
R	2011	ALL	Chassis	Electronic Brake Control Module													V																																											
R	2011	ALL	Body	Body Control Module			V																												V			V																							
R	2011	ALL	Body	Digital Radio Receiver																																																								
R	2011	ALL	Body	Driver Door Switch																																																								
R	2011	ALL	Body	Head Up Display																																																								
R	2011	ALL	Body	Heated Seat Module																																																								
R	2011	ALL	Body	HVAC Control Module Auto																																																								
R	2011	ALL	Body	HVAC Control Module Manual																																																								
R	2011	ALL	Body	Instrument Panel Cluster																																																								
R	2011	ALL	Body	Lift Gate Module																																																								
R	2011	ALL	Body	Park Assist Module																																																								
R	2011	ALL	Body	Passenger Door Switch																																																								
R	2011	ALL	Body	Passenger Presence System																																																								
R	2011	ALL	Body	Radio																																																								
R	2011	ALL	Body	Rear HVAC/RSA																																																								
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2011	ALL	Body	Theft Deterrent Module		V																																																						
R	2012	ALL	Powertrain	Engine Control Module					V																																																				V
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2012	ALL	Powertrain	Transmission Control Module																																																								
R	2012	ALL	Chassis	Electronic Brake Control Module													V																																											
R	2012	ALL	Body	Body Control Module			V																												V			V																							
R	2012	ALL	Body	Digital Radio Receiver																																																								
R	2012	ALL	Body	Driver Door Switch																																																								
R	2012	ALL	Body	Head Up Display																																																								
R	2012	ALL	Body	Heated Seat Module																																																								
R	2012	ALL	Body	HVAC Control Module Auto																																																								
R	2012	ALL	Body	HVAC Control Module Manual																																																								
R	2012	ALL	Body	Instrument Panel Cluster																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2012	ALL	Body	Lift Gate Module																																																								
R	2012	ALL	Body	Park Assist Module																																																								
R	2012	ALL	Body	Passenger Door Switch																																																								
R	2012	ALL	Body	Passenger Presence System																																																								
R	2012	ALL	Body	Radio																																																								
R	2012	ALL	Body	Rear HVAC/RSA																																																								
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2012	ALL	Body	Theft Deterrent Module		V																																																						
R	2013	ALL	Powertrain	Engine Control Module					V																																																			V
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2013	ALL	Powertrain	Transmission Control Module																																																								
R	2013	ALL	Chassis	Electronic Brake Control Module													V																																										
R	2013	ALL	Body	Body Control Module			V																													V			V																					
R	2013	ALL	Body	Digital Radio Receiver																																																								
R	2013	ALL	Body	Driver Door Switch																																																								
R	2013	ALL	Body	Head Up Display																																																								
R	2013	ALL	Body	Heated Seat Module																																																								
R	2013	ALL	Body	HVAC Control Module Auto																																																								
R	2013	ALL	Body	HVAC Control Module Manual																																																								
R	2013	ALL	Body	Instrument Panel Cluster																																																								
R	2013	ALL	Body	Left Side Object Detection Module																																																								
R	2013	ALL	Body	Lift Gate Module																																																								
R	2013	ALL	Body	Park Assist Module																																																								
R	2013	ALL	Body	Passenger Door Switch																																																								
R	2013	ALL	Body	Passenger Presence System																																																								
R	2013	ALL	Body	Radio																																																								
R	2013	ALL	Body	Rear HVAC/RSA																																																								
R	2013	ALL	Body	Right Side Object Detection Module																																																								
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2013	ALL	Body	Theft Deterrent Module		V																																																						
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2014	Acadia	Powertrain	Chassis Control Module																																																								
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																								
R	2014	Acadia	Chassis	Electronic Brake Control Module																																																								
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																								
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																								
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2014	Acadia	Body	Passenger Presence Module																																																								
R	2014	Acadia	Body	Instrument Cluster																																																								
R	2014	Acadia	Body	Head-Up Display Module																																																								
R	2014	Acadia	Body	Radio																																																								
R	2014	Acadia	Body	Rear Audio Control Module																																																								
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																								
R	2014	Acadia	Body	Personal Audio Link Control Module																																																								
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																								
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																								
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2014	Acadia	Body	Liftgate Control Module																																																										
R	2014	Acadia	Body	Seat Memory Control Module																																																											
R	2014	Acadia	Body	Front Seat Heating Control Module																																																											
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																											
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																											
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																											
R	2014	Acadia	Body	Parking Assist Control Module																																																											
R	2014	Acadia	Body	Frontview Camera Module																																																											
R	2014	Acadia	Body	Theft Deterrent Module		V																																																									
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																											
R	2015	Acadia	Chassis	Electronic Brake Control Module																																																											
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																											
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																											
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2015	Acadia	Body	Passenger Presence Module																																																											
R	2015	Acadia	Body	Instrument Cluster																																																											
R	2015	Acadia	Body	Head-Up Display Module																																																											
R	2015	Acadia	Body	Radio																																																											
R	2015	Acadia	Body	Rear Audio Control Module																																																											
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																											
R	2015	Acadia	Body	Personal Audio Link Control Module																																																											
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																											
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																											
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																											
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																											
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																											
R	2015	Acadia	Body	Liftgate Control Module																																																											
R	2015	Acadia	Body	Seat Memory Control Module																																																											
R	2015	Acadia	Body	Front Seat Heating Control Module																																																											
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																											
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																											
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																											
R	2015	Acadia	Body	Parking Assist Control Module																																																											
R	2015	Acadia	Body	Frontview Camera Module																																																											
R	2015	Acadia	Body	Theft Deterrent Module		V																																																									
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																											
R	2016	Acadia	Chassis	Electronic Brake Control Module																																																											
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																											
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																											
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
R	2016	Acadia	Body	Passenger Presence Module																																																											
R	2016	Acadia	Body	Instrument Cluster																																																											
R	2016	Acadia	Body	Head-Up Display Module																																																											
R	2016	Acadia	Body	Radio																																																											
R	2016	Acadia	Body	Rear Audio Control Module																																																											
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
R	2016	Acadia	Body	Personal Audio Link Control Module																																																										
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																										
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Acadia	Body	Liftgate Control Module																																																										
R	2016	Acadia	Body	Seat Memory Control Module																																																										
R	2016	Acadia	Body	Front Seat Heating Control Module																																																										
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																										
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																										
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																										
R	2016	Acadia	Body	Parking Assist Control Module																																																										
R	2016	Acadia	Body	Frontview Camera Module																																																										
R	2016	Acadia	Body	Theft Deterrent Module		V																																																								
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																										
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Sonoma	Body	Body Control Module																												V																														
S	2004	Sonoma	Body	Instrument Panel Cluster																																																										
S	2004	Sonoma	Body	Base Radio																																																										
S	2004	Sonoma	Body	Uplevel Radio																																																										
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																										
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module			V		V																																																					
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module			V		V																																																					
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2004	Canyon	Chassis	ABS Without Traction Control																																																										
S	2004	Canyon	Chassis	ABS With Traction Control																																																										
S	2004	Canyon	Body	Body Control Module																												V													V																
S	2004	Canyon	Body	Instrument Panel Cluster																																																										
S	2004	Canyon	Body	OnStar																																																V	V							
S	2004	Canyon	Body	Base Radio																																																										
S	2004	Canyon	Body	Uplevel Radio																																																										
S	2004	Canyon	Body	Supplemental Inflatable Restraint	V																																																									
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy	Body	Amplifier (Bose)																																																										
S	2004	Envoy	Body	Body Control Module																																																										
S	2004	Envoy	Body	Driver Door Module																																																										
S	2004	Envoy	Body	Driver Seat Module																			V																																							
S	2004	Envoy	Body	Heating and Air Conditioning Auto																			V																																							
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy	Body	Instrument Panel Cluster																																																										
S	2004	Envoy	Body	Lift Gate Module																																																										
S	2004	Envoy	Body	OnStar																																																V	V							
S	2004	Envoy	Body	Passenger Door Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2004	Envoy	Body	Uplevel Radio																																																										
S	2004	Envoy	Body	Navigation Radio								V																																																	
S	2004	Envoy	Body	Rear Seat Audio																																																										
S	2004	Envoy	Body	Rear Seat Entertainment																																																										
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy	Body	Vehicle Theft Deterrent		V																																																								
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module			V	V	V																																																					
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy XL	Body	Amplifier (Bose)																																																										
S	2004	Envoy XL	Body	Body Control Module																																																										
S	2004	Envoy XL	Body	Driver Door Module																																																										
S	2004	Envoy XL	Body	Driver Seat Module																			V																																								
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																			V																																								
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																										
S	2004	Envoy XL	Body	Lift Gate Module																																																										
S	2004	Envoy XL	Body	OnStar																																																V	V								
S	2004	Envoy XL	Body	Passenger Door Module																																																										
S	2004	Envoy XL	Body	Uplevel Radio																																																										
S	2004	Envoy XL	Body	Navigation Radio								V																																																		
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
S	2004	Envoy XL	Body	Rear HVAC Manual																																																										
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																										
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy XL	Body	Vehicle Theft Deterrent		V																																																								
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module			V	V	V																																																					
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																										
S	2004	Envoy XUV	Body	Body Control Module																																																										
S	2004	Envoy XUV	Body	Driver Door Module																																																										
S	2004	Envoy XUV	Body	Driver Seat Module																			V																																								
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																			V																																								
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																										
S	2004	Envoy XUV	Body	Lift Gate Module																																																										
S	2004	Envoy XUV	Body	OnStar																																																V	V								
S	2004	Envoy XUV	Body	Passenger Door Module																																																										
S	2004	Envoy XUV	Body	Uplevel Radio																																																										
S	2004	Envoy XUV	Body	Navigation Radio								V																																																		
S	2004	Envoy XUV	Body	Rear Seat Audio																																																										
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																								
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent		V																																																						
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																			
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																								
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																							
S	2004	Jimmy	Body	Body Control Module																												V																												
S	2004	Jimmy	Body	Heating and Air Conditioning																																																								
S	2004	Jimmy	Body	Instrument Panel Cluster																																																								
S	2004	Jimmy	Body	Memory Seat Module																																																								
S	2004	Jimmy	Body	Base Radio																																																								
S	2004	Jimmy	Body	Uplevel Radio																																																								
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																								
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module			V		V																																																			
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																								
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module			V		V																																																			
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																								
S	2005	Canyon	Chassis	ABS Without Traction Control																																																								
S	2005	Canyon	Chassis	ABS With Traction Control																																																								
S	2005	Canyon	Body	Body Control Module																												V												V																
S	2005	Canyon	Body	Instrument Panel Cluster																																																								
S	2005	Canyon	Body	Base Radio																																																								
S	2005	Canyon	Body	Uplevel Radio																																																								
S	2005	Canyon	Body	Supplemental Inflatable Restraint	V																																																							
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																																V	V	V						
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																			
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																		
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
S	2005	Envoy	Chassis	ABS Without Traction Control																																																								
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																								
S	2005	Envoy	Body	Body Control Module																																																								
S	2005	Envoy	Body	Disc Player and Video Display																																																								
S	2005	Envoy	Body	Driver Door Module																																																								
S	2005	Envoy	Body	Driver Seat Module																			V																																					
S	2005	Envoy	Body	Heating and Air Conditioning Auto																			V																																					
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																																								
S	2005	Envoy	Body	Instrument Panel Cluster																																																								
S	2005	Envoy	Body	Lift Gate Module																																																								
S	2005	Envoy	Body	Passenger Door Module																																																								
S	2005	Envoy	Body	Passenger Presence System																																																								
S	2005	Envoy	Body	Uplevel Radio																																																								
S	2005	Envoy	Body	Navigation Radio								V																																																
S	2005	Envoy	Body	Rear Seat Audio																																																								
S	2005	Envoy	Body	Supplemental Inflatable Restraint	V																																																							
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																																V	V	V						
S	2005	Envoy	Body	Vehicle Theft Deterrent		V																																																						
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																			
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																			

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy XL	Body	Body Control Module																																																										
S	2005	Envoy XL	Body	Disc Player and Video Display																																																										
S	2005	Envoy XL	Body	Driver Door Module																																																										
S	2005	Envoy XL	Body	Driver Seat Module																			V																																								
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																			V																																							
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy XL	Body	Instrument Panel Cluster																																																										
S	2005	Envoy XL	Body	Lift Gate Module																																																										
S	2005	Envoy XL	Body	Passenger Door Module																																																										
S	2005	Envoy XL	Body	Passenger Presence System																																																										
S	2005	Envoy XL	Body	Uplevel Radio																																																										
S	2005	Envoy XL	Body	Navigation Radio								V																																																	
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
S	2005	Envoy XL	Body	Rear HVAC Manual																																																										
S	2005	Envoy XL	Body	Rear Seat Audio																																																										
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint	V																																																									
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																V	V	V						
S	2005	Envoy XL	Body	Vehicle Theft Deterrent		V																																																							
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																				
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																				
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy XUV	Body	Body Control Module																																																										
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																										
S	2005	Envoy XUV	Body	Driver Door Module																																																										
S	2005	Envoy XUV	Body	Driver Seat Module																			V																																								
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																			V																																							
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																																										
S	2005	Envoy XUV	Body	Lift Gate Module																																																										
S	2005	Envoy XUV	Body	Passenger Door Module																																																										
S	2005	Envoy XUV	Body	Passenger Presence System																																																										
S	2005	Envoy XUV	Body	Uplevel Radio																																																										
S	2005	Envoy XUV	Body	Navigation Radio								V																																																	
S	2005	Envoy XUV	Body	Rear Seat Audio																																																										
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint	V																																																									
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																V	V	V						
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent		V																																																							
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																										
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Jimmy	Body	Body Control Module																												V																														
S	2005	Jimmy	Body	Heating and Air Conditioning																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2005	Jimmy	Body	Instrument Panel Cluster																																																										
S	2005	Jimmy	Body	Memory Seat Module																																																										
S	2005	Jimmy	Body	Base Radio																																																										
S	2005	Jimmy	Body	Uplevel Radio																																																										
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																					
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																										
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Sonoma	Body	Body Control Module																													V																													
S	2005	Sonoma	Body	Instrument Panel Cluster																																																										
S	2005	Sonoma	Body	Base Radio																																																										
S	2005	Sonoma	Body	Uplevel Radio																																																										
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																										
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module			V		V																																																					
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module			V		V																																																					
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2006	Canyon	Chassis	ABS Without Traction Control																																																										
S	2006	Canyon	Chassis	ABS With Traction Control																																																										
S	2006	Canyon	Body	Body Control Module																													V												V																	
S	2006	Canyon	Body	Instrument Panel Cluster																																																										
S	2006	Canyon	Body	Passenger Presence System																																																										
S	2006	Canyon	Body	Base Radio																																																										
S	2006	Canyon	Body	Uplevel Radio																																																										
S	2006	Canyon	Body	Supplemental Inflatable Restraint	V																																																									
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																																V	V	V								
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																					
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module			V		V																																																					
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2006	Envoy	Chassis	ABS/TCS/VSES																																																										
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																										
S	2006	Envoy	Body	Body Control Module																													V																													
S	2006	Envoy	Body	Disc Player and Video Display																																																										
S	2006	Envoy	Body	Driver Door Module																																																										
S	2006	Envoy	Body	Driver Seat Module																			V																																							
S	2006	Envoy	Body	Heating and Air Conditioning Auto																			V																																							
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2006	Envoy	Body	Instrument Panel Cluster																																																										
S	2006	Envoy	Body	Lift Gate Module																																																										
S	2006	Envoy	Body	Passenger Door Module																																																										
S	2006	Envoy	Body	Passenger Presence System																																																										
S	2006	Envoy	Body	Uplevel Radio																																																										
S	2006	Envoy	Body	Navigation Radio								V																																																		
S	2006	Envoy	Body	Rear Seat Audio																																																										
S	2006	Envoy	Body	Supplemental Inflatable Restraint	V																																																									
S	2006	Envoy	Body	Vehicle Theft Deterrent		V																																																								
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																																V	V	V								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																				
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																					
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																										
S	2006	Envoy XL	Body	Body Control Module																												V																														
S	2006	Envoy XL	Body	Disc Player and Video Display																																																										
S	2006	Envoy XL	Body	Driver Door Module																																																										
S	2006	Envoy XL	Body	Driver Seat Module																			V																																							
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																			V																																							
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
S	2006	Envoy XL	Body	Instrument Panel Cluster																																																										
S	2006	Envoy XL	Body	Lift Gate Module																																																										
S	2006	Envoy XL	Body	Passenger Door Module																																																										
S	2006	Envoy XL	Body	Passenger Presence System																																																										
S	2006	Envoy XL	Body	Uplevel Radio																																																										
S	2006	Envoy XL	Body	Navigation Radio								V																																																	
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
S	2006	Envoy XL	Body	Rear HVAC Manual																																																										
S	2006	Envoy XL	Body	Rear Seat Audio																																																										
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint	V																																																									
S	2006	Envoy XL	Body	Vehicle Theft Deterrent		V																																																								
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																V	V	V						
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module			V		V																																																				
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module			V		V																																																				
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																										
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																										
S	2007	Canyon	Body	Body Control Module																												V												V		V															
S	2007	Canyon	Body	Digital Radio Receiver																																																										
S	2007	Canyon	Body	Generator Battery Control Module																																																										
S	2007	Canyon	Body	Instrument Panel Cluster																																																										
S	2007	Canyon	Body	Passenger Presence System																																																										
S	2007	Canyon	Body	Base Radio																																																									
S	2007	Canyon	Body	Uplevel Radio																																																										
S	2007	Canyon	Body	Supplemental Inflatable Restraint	V																																																									
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																																V	V	V						
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module			V		V																																																					
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																										
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																															V			V
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																															V			V
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2007	Envoy	Chassis	Electronic Brake Control Module																																																										
S	2007	Envoy	Body	Body Control Module																												V																														
S	2007	Envoy	Body	Digital Radio Receiver																																																										
S	2007	Envoy	Body	Disc Player and Video Display																																																										
S	2007	Envoy	Body	Driver Door Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2007	Envoy	Body	Driver Seat Module																			V																																					
S	2007	Envoy	Body	Generator Battery Control Module																																																							
S	2007	Envoy	Body	HVAC Control Module Auto																			V										V																											
S	2007	Envoy	Body	HVAC Control Module Manual																																																							
S	2007	Envoy	Body	Instrument Panel Cluster																																																							
S	2007	Envoy	Body	Lift Gate Module																																										V													
S	2007	Envoy	Body	Passenger Door Module																																																							
S	2007	Envoy	Body	Passenger Presence System																																																							
S	2007	Envoy	Body	Uplevel Radio																																																							
S	2007	Envoy	Body	Navigation Radio								V																																															
S	2007	Envoy	Body	Rear Seat Audio																																																							
S	2007	Envoy	Body	Supplemental Inflatable Restraint	V																																																							
S	2007	Envoy	Body	Theft Deterrent Module		V																																																						
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																															V	V	V						
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																															V		V
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																							
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																	V
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																							
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																							
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																							
S	2008	Canyon	Body	Body Control Module																																								V		V													
S	2008	Canyon	Body	Digital Radio Receiver																																																							
S	2008	Canyon	Body	Generator Battery Control Module																																																							
S	2008	Canyon	Body	Instrument Panel Cluster																																																							
S	2008	Canyon	Body	Passenger Presence System																																																							
S	2008	Canyon	Body	Base Radio																																																							
S	2008	Canyon	Body	Uplevel Radio																																																							
S	2008	Canyon	Body	Supplemental Inflatable Restraint	V																																																							
S	2008	Canyon	Body	Theft Deterrent Module		V																																																						
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																															V	V	V						
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module					V																																																	V
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																							
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																														V		V
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																							
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																														V		V
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																							
S	2008	Envoy	Chassis	Electronic Brake Control Module																																																							
S	2008	Envoy	Body	Body Control Module																												V																											
S	2008	Envoy	Body	Digital Radio Receiver																																																							
S	2008	Envoy	Body	Disc Player and Video Display																																																							
S	2008	Envoy	Body	Driver Door Module																																																							
S	2008	Envoy	Body	Driver Seat Module																			V																																					
S	2008	Envoy	Body	Generator Battery Control Module																																																							
S	2008	Envoy	Body	HVAC Control Module Auto																			V										V																											
S	2008	Envoy	Body	HVAC Control Module Manual																																																							
S	2008	Envoy	Body	Instrument Panel Cluster																																																							
S	2008	Envoy	Body	Lift Gate Module																																										V													
S	2008	Envoy	Body	Passenger Door Module																																																							
S	2008	Envoy	Body	Passenger Presence System																																																							
S	2008	Envoy	Body	Uplevel Radio																																																							
S	2008	Envoy	Body	Navigation Radio								V																																															

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2008	Envoy	Body	Rear Seat Audio																																																										
S	2008	Envoy	Body	Supplemental Inflatable Restraint	V																																																									
S	2008	Envoy	Body	Theft Deterrent Module		V																																																								
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																															V	V	V							
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																															V		V
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																							
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																							
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																		V
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																							
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																							
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module					V																																														V		V
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																						
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																						
S	2009	Canyon	Chassis	Electronic Brake Control Module										V	V																																												
S	2009	Canyon	Body	Body Control Module																																								V		V													
S	2009	Canyon	Body	Digital Radio Receiver																																																						
S	2009	Canyon	Body	Generator Battery Control Module																																																						
S	2009	Canyon	Body	Instrument Panel Cluster																																																						
S	2009	Canyon	Body	Passenger Presence System																																																						
S	2009	Canyon	Body	Base Radio																																																						
S	2009	Canyon	Body	Uplevel Radio																																																						
S	2009	Canyon	Body	Supplemental Inflatable Restraint	V																																																						
S	2009	Canyon	Body	Theft Deterrent Module		V																																																						
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module					V																																																		V
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																						
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																						
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																														V		V
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																						
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																						
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																														V		V
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																						
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																						
S	2009	Envoy	Chassis	Electronic Brake Control Module																																																						
S	2009	Envoy	Body	Body Control Module																												V																											
S	2009	Envoy	Body	Digital Radio Receiver																																																						
S	2009	Envoy	Body	Disc Player and Video Display																																																						
S	2009	Envoy	Body	Driver Door Module																																																						
S	2009	Envoy	Body	Driver Seat Module																			V																																				
S	2009	Envoy	Body	Generator Battery Control Module																																																						
S	2009	Envoy	Body	HVAC Control Module Auto																			V									V																											
S	2009	Envoy	Body	HVAC Control Module Manual																																																						
S	2009	Envoy	Body	Instrument Panel Cluster																																																						
S	2009	Envoy	Body	Lift Gate Module																																										V													
S	2009	Envoy	Body	Passenger Door Module																																																						
S	2009	Envoy	Body	Passenger Presence System																																																						
S	2009	Envoy	Body	Uplevel Radio																																																						
S	2009	Envoy	Body	Navigation Radio								V																																														
S	2009	Envoy	Body	Rear Seat Audio																																																						
S	2009	Envoy	Body	Supplemental Inflatable Restraint	V																																																					
S	2009	Envoy	Body	Theft Deterrent Module		V																																																					
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																														V		V

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																					V
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module					V																																														V			V
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
S	2010	ALL	Chassis	Electronic Brake Control Module											V	V																																														
S	2010	ALL	Body	Body Control Module																																								V		V															
S	2010	ALL	Body	Digital Radio Receiver																																																									
S	2010	ALL	Body	Generator Battery Control Module																																																									
S	2010	ALL	Body	Instument Panel Cluster																																																									
S	2010	ALL	Body	Passenger Presence System																																																									
S	2010	ALL	Body	Personal Audio Link Module																																																									
S	2010	ALL	Body	Base Radio																																																									
S	2010	ALL	Body	Uplevel Radio																																																									
S	2010	ALL	Body	Supplemental Inflatable Restraint	V																																																									
S	2010	ALL	Body	Theft Deterrent Module		V																																																							
S	2010	ALL	Body	Vehicle Comm. Interface Module																																															V			V						
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																				
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																									
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Sonoma	Body	Body Control Module																												V																														
T	2004	Sonoma	Body	Instrument Panel Cluster																																																									
T	2004	Sonoma	Body	Base Radio																																																									
T	2004	Sonoma	Body	Uplevel Radio																																																									
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																									
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module			V		V																																																				
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																									
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module			V		V																																																				
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																									
T	2004	Canyon	Chassis	ABS Without Traction Control																																																									
T	2004	Canyon	Chassis	ABS With Traction Control																																																									
T	2004	Canyon	Body	Body Control Module																												V												V																	
T	2004	Canyon	Body	Instrument Panel Cluster																																																									
T	2004	Canyon	Body	OnStar																																														V	V								
T	2004	Canyon	Body	Base Radio																																																									
T	2004	Canyon	Body	Uplevel Radio																																																									
T	2004	Canyon	Body	Supplemental Inflatable Restraint	V																																																									
T	2004	Canyon	Body	Instrument Panel Cluster																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																				
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																									
T	2004	Envoy	Chassis	ABS Without Traction Control																																																									
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Envoy	Body	Amplifier (Bose)																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2004	Envoy	Body	Body Control Module																																																										
T	2004	Envoy	Body	Driver Door Module																																																										
T	2004	Envoy	Body	Driver Seat Module																			V																																							
T	2004	Envoy	Body	Heating and Air Conditioning Auto																			V																																							
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																																										
T	2004	Envoy	Body	Instrument Panel Cluster																																																										
T	2004	Envoy	Body	Lift Gate Module																																																										
T	2004	Envoy	Body	OnStar																																																V	V								
T	2004	Envoy	Body	Passenger Door Module																																																										
T	2004	Envoy	Body	Uplevel Radio																																																										
T	2004	Envoy	Body	Navigation Radio								V																																																		
T	2004	Envoy	Body	Rear Seat Audio																																																										
T	2004	Envoy	Body	Rear Seat Entertainment																																																										
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy	Body	Vehicle Theft Deterrent		V																																																								
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module			V	V	V																																																					
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy XL	Body	Amplifier (Bose)																																																										
T	2004	Envoy XL	Body	Body Control Module																																																										
T	2004	Envoy XL	Body	Driver Door Module																																																										
T	2004	Envoy XL	Body	Driver Seat Module																			V																																							
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																			V																																							
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2004	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2004	Envoy XL	Body	Lift Gate Module																																																										
T	2004	Envoy XL	Body	OnStar																																																V	V								
T	2004	Envoy XL	Body	Passenger Door Module																																																										
T	2004	Envoy XL	Body	Uplevel Radio																																																										
T	2004	Envoy XL	Body	Navigation Radio								V																																																		
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2004	Envoy XL	Body	Rear HVAC Manual																																																										
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																										
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy XL	Body	Vehicle Theft Deterrent		V																																																								
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module			V	V	V																																																					
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2004	Envoy XUV	Body	Body Control Module																																																								
T	2004	Envoy XUV	Body	Driver Door Module																																																								
T	2004	Envoy XUV	Body	Driver Seat Module																			V																																					
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																			V																																					
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																								
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																																								
T	2004	Envoy XUV	Body	Lift Gate Module																																																								
T	2004	Envoy XUV	Body	OnStar																																																V	V						
T	2004	Envoy XUV	Body	Passenger Door Module																																																								
T	2004	Envoy XUV	Body	Uplevel Radio																																																								
T	2004	Envoy XUV	Body	Navigation Radio								V																																																
T	2004	Envoy XUV	Body	Rear Seat Audio																																																								
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																								
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																								
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent		V																																																						
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																			
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																								
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																								
T	2004	Jimmy	Body	Body Control Module																												V																												
T	2004	Jimmy	Body	Heating and Air Conditioning																																																								
T	2004	Jimmy	Body	Instrument Panel Cluster																																																								
T	2004	Jimmy	Body	Memory Seat Module																																																								
T	2004	Jimmy	Body	Base Radio																																																								
T	2004	Jimmy	Body	Uplevel Radio																																																								
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																								
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module			V		V																																																			
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																								
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module			V		V																																																			
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																								
T	2005	Canyon	Chassis	ABS Without Traction Control																																																								
T	2005	Canyon	Chassis	ABS With Traction Control																																																								
T	2005	Canyon	Body	Body Control Module																												V													V															
T	2005	Canyon	Body	Instrument Panel Cluster																																																								
T	2005	Canyon	Body	Base Radio																																																								
T	2005	Canyon	Body	Uplevel Radio																																																								
T	2005	Canyon	Body	Supplemental Inflatable Restraint	V																																																							
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																																V	V	V						
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																			
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																								
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable				V	V																																																			
T	2005	Envoy	Chassis	ABS Without Traction Control																																																								
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																								
T	2005	Envoy	Body	Body Control Module																																																								
T	2005	Envoy	Body	Disc Player and Video Display																																																								
T	2005	Envoy	Body	Driver Door Module																																																								
T	2005	Envoy	Body	Driver Seat Module																			V																																					
T	2005	Envoy	Body	Heating and Air Conditioning Auto																			V																																					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																																								
T	2005	Envoy	Body	Instrument Panel Cluster																																																								
T	2005	Envoy	Body	Lift Gate Module																																																								
T	2005	Envoy	Body	Passenger Door Module																																																								
T	2005	Envoy	Body	Passenger Presence System																																																								
T	2005	Envoy	Body	Uplevel Radio																																																								
T	2005	Envoy	Body	Navigation Radio								V																																																
T	2005	Envoy	Body	Rear Seat Audio																																																								
T	2005	Envoy	Body	Supplemental Inflatable Restraint	V																																																							
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																																V	V	V						
T	2005	Envoy	Body	Vehicle Theft Deterrent		V																																																						
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																			
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																			
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																								
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																								
T	2005	Envoy XL	Body	Body Control Module																																																								
T	2005	Envoy XL	Body	Disc Player and Video Display																																																								
T	2005	Envoy XL	Body	Driver Door Module																																																								
T	2005	Envoy XL	Body	Driver Seat Module																			V																																					
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																			V																																					
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																								
T	2005	Envoy XL	Body	Instrument Panel Cluster																																																								
T	2005	Envoy XL	Body	Lift Gate Module																																																								
T	2005	Envoy XL	Body	Passenger Door Module																																																								
T	2005	Envoy XL	Body	Passenger Presence System																																																								
T	2005	Envoy XL	Body	Uplevel Radio																																																								
T	2005	Envoy XL	Body	Navigation Radio								V																																																
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																								
T	2005	Envoy XL	Body	Rear HVAC Manual																																																								
T	2005	Envoy XL	Body	Rear Seat Audio																																																								
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint	V																																																							
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																V	V	V						
T	2005	Envoy XL	Body	Vehicle Theft Deterrent		V																																																						
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																			
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																			
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																								
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																								
T	2005	Envoy XUV	Body	Body Control Module																																																								
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																								
T	2005	Envoy XUV	Body	Driver Door Module																																																								
T	2005	Envoy XUV	Body	Driver Seat Module																			V																																					

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																			V																																					
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																								
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																																								
T	2005	Envoy XUV	Body	Lift Gate Module																																																								
T	2005	Envoy XUV	Body	Passenger Door Module																																																								
T	2005	Envoy XUV	Body	Passenger Presence System																																																								
T	2005	Envoy XUV	Body	Uplevel Radio																																																								
T	2005	Envoy XUV	Body	Navigation Radio								V																																															
T	2005	Envoy XUV	Body	Rear Seat Audio																																																								
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint	V																																																							
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																V	V	V					
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent		V																																																						
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																			
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																								
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																								
T	2005	Jimmy	Body	Body Control Module																												V																												
T	2005	Jimmy	Body	Heating and Air Conditioning																																																								
T	2005	Jimmy	Body	Instrument Panel Cluster																																																								
T	2005	Jimmy	Body	Memory Seat Module																																																								
T	2005	Jimmy	Body	Base Radio																																																								
T	2005	Jimmy	Body	Uplevel Radio																																																								
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																								
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V	V																																																			
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																								
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																								
T	2005	Sonoma	Body	Body Control Module																												V																												
T	2005	Sonoma	Body	Instrument Panel Cluster																																																								
T	2005	Sonoma	Body	Base Radio																																																								
T	2005	Sonoma	Body	Uplevel Radio																																																								
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																								
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module			V		V																																																			
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																								
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module			V		V																																																			
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																								
T	2006	Canyon	Chassis	ABS Without Traction Control																																																								
T	2006	Canyon	Chassis	ABS With Traction Control																																																								
T	2006	Canyon	Body	Body Control Module																												V												V																
T	2006	Canyon	Body	Instrument Panel Cluster																																																								
T	2006	Canyon	Body	Passenger Presence System																																																								
T	2006	Canyon	Body	Base Radio																																																								
T	2006	Canyon	Body	Uplevel Radio																																																								
T	2006	Canyon	Body	Supplemental Inflatable Restraint	V																																																							
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																																V	V	V					
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																			
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																			

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module			V		V																																																			
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
T	2006	Envoy	Chassis	ABS/TCS/VSES																																																								
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																								
T	2006	Envoy	Body	Body Control Module																													V																											
T	2006	Envoy	Body	Disc Player and Video Display																																																								
T	2006	Envoy	Body	Driver Door Module																																																								
T	2006	Envoy	Body	Driver Seat Module																			V																																					
T	2006	Envoy	Body	Heating and Air Conditioning Auto																			V																																					
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																																								
T	2006	Envoy	Body	Instrument Panel Cluster																																																								
T	2006	Envoy	Body	Lift Gate Module																																																								
T	2006	Envoy	Body	Passenger Door Module																																																								
T	2006	Envoy	Body	Passenger Presence System																																																								
T	2006	Envoy	Body	Uplevel Radio																																																								
T	2006	Envoy	Body	Navigation Radio								V																																																
T	2006	Envoy	Body	Rear Seat Audio																																																								
T	2006	Envoy	Body	Supplemental Inflatable Restraint	V																																																								
T	2006	Envoy	Body	Vehicle Theft Deterrent		V																																																							
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																																V	V	V						
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																			
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module			V		V																																																			
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																								
T	2006	Envoy XL	Body	Body Control Module																													V																											
T	2006	Envoy XL	Body	Disc Player and Video Display																																																								
T	2006	Envoy XL	Body	Driver Door Module																																																								
T	2006	Envoy XL	Body	Driver Seat Module																			V																																					
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																			V																																					
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																								
T	2006	Envoy XL	Body	Instrument Panel Cluster																																																								
T	2006	Envoy XL	Body	Lift Gate Module																																																								
T	2006	Envoy XL	Body	Passenger Door Module																																																								
T	2006	Envoy XL	Body	Passenger Presence System																																																								
T	2006	Envoy XL	Body	Uplevel Radio																																																								
T	2006	Envoy XL	Body	Navigation Radio								V																																																
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																								
T	2006	Envoy XL	Body	Rear HVAC Manual																																																								
T	2006	Envoy XL	Body	Rear Seat Audio																																																								
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint	V																																																							
T	2006	Envoy XL	Body	Vehicle Theft Deterrent		V																																																						
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																V	V	V						
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module			V		V																																																			
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module			V		V																																																			

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																										
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																										
T	2007	Canyon	Body	Body Control Module																													V												V		V															
T	2007	Canyon	Body	Digital Radio Receiver																																																										
T	2007	Canyon	Body	Generator Battery Control Module																																																										
T	2007	Canyon	Body	Instrument Panel Cluster																																																										
T	2007	Canyon	Body	Passenger Presence System																																																										
T	2007	Canyon	Body	Base Radio																																																										
T	2007	Canyon	Body	Uplevel Radio																																																										
T	2007	Canyon	Body	Supplemental Inflatable Restraint	V																																																									
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																																V	V	V								
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module			V		V																																																					
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module			V		V																																																					
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																										
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																															V			V			
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																															V			V			
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																										
T	2007	Envoy	Chassis	Electronic Brake Control Module																																																										
T	2007	Envoy	Body	Body Control Module																													V																													
T	2007	Envoy	Body	Digital Radio Receiver																																																										
T	2007	Envoy	Body	Disc Player and Video Display																																																										
T	2007	Envoy	Body	Driver Door Module																																																										
T	2007	Envoy	Body	Driver Seat Module																			V																																							
T	2007	Envoy	Body	Generator Battery Control Module																																																										
T	2007	Envoy	Body	HVAC Control Module Auto																			V										V																													
T	2007	Envoy	Body	HVAC Control Module Manual																																																										
T	2007	Envoy	Body	Instrument Panel Cluster																																																										
T	2007	Envoy	Body	Lift Gate Module																																										V																
T	2007	Envoy	Body	Passenger Door Module																																																										
T	2007	Envoy	Body	Passenger Presence System																																																										
T	2007	Envoy	Body	Uplevel Radio																																																										
T	2007	Envoy	Body	Navigation Radio								V																																																		
T	2007	Envoy	Body	Rear Seat Audio																																																										
T	2007	Envoy	Body	Supplemental Inflatable Restraint	V																																																									
T	2007	Envoy	Body	Theft Deterrent Module		V																																																								
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																																V	V	V								
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																																V			V		
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																				V	
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2008	Canyon	Body	Body Control Module																																									V		V												
T	2008	Canyon	Body	Digital Radio Receiver																																																						
T	2008	Canyon	Body	Generator Battery Control Module																																																						
T	2008	Canyon	Body	Instrument Panel Cluster																																																						
T	2008	Canyon	Body	Passenger Presence System																																																						
T	2008	Canyon	Body	Base Radio																																																						
T	2008	Canyon	Body	Uplevel Radio																																																						
T	2008	Canyon	Body	Supplemental Inflatable Restraint	V																																																					
T	2008	Canyon	Body	Theft Deterrent Module		V																																																				
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																															V	V	V					
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module					V																																																V
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																					
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																					
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																												V			V
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																				
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																				
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																												V			V
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																				
T	2008	Envoy	Chassis	Electronic Brake Control Module																																																				
T	2008	Envoy	Body	Body Control Module																												V																										
T	2008	Envoy	Body	Digital Radio Receiver																																																					
T	2008	Envoy	Body	Disc Player and Video Display																																																					
T	2008	Envoy	Body	Driver Door Module																																																					
T	2008	Envoy	Body	Driver Seat Module																			V																																			
T	2008	Envoy	Body	Generator Battery Control Module																																																					
T	2008	Envoy	Body	HVAC Control Module Auto																			V									V																										
T	2008	Envoy	Body	HVAC Control Module Manual																																																					
T	2008	Envoy	Body	Instrument Panel Cluster																																																					
T	2008	Envoy	Body	Lift Gate Module																																										V												
T	2008	Envoy	Body	Passenger Door Module																																																					
T	2008	Envoy	Body	Passenger Presence System																																																					
T	2008	Envoy	Body	Uplevel Radio																																																					
T	2008	Envoy	Body	Navigation Radio								V																																													
T	2008	Envoy	Body	Rear Seat Audio																																																					
T	2008	Envoy	Body	Supplemental Inflatable Restraint	V																																																				
T	2008	Envoy	Body	Theft Deterrent Module		V																																																			
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																														V	V	V					
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																													V		V
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																					
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																					
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																					
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																															V
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																					
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																					
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																					
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module					V																																												V			V
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																					
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																					
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																					
T	2009	Canyon	Chassis	Electronic Brake Control Module											V	V																																										
T	2009	Canyon	Body	Body Control Module																																									V		V												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2009	Canyon	Body	Digital Radio Receiver																																																								
T	2009	Canyon	Body	Generator Battery Control Module																																																								
T	2009	Canyon	Body	Instrument Panel Cluster																																																								
T	2009	Canyon	Body	Passenger Presence System																																																								
T	2009	Canyon	Body	Base Radio																																																								
T	2009	Canyon	Body	Uplevel Radio																																																								
T	2009	Canyon	Body	Supplemental Inflatable Restraint	V																																																								
T	2009	Canyon	Body	Theft Deterrent Module		V																																																							
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module					V																																																				V
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																									
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																															V			V
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																															V			V
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																									
T	2009	Envoy	Body	Body Control Module																												V																														
T	2009	Envoy	Body	Digital Radio Receiver																																																									
T	2009	Envoy	Body	Disc Player and Video Display																																																									
T	2009	Envoy	Body	Driver Door Module																																																									
T	2009	Envoy	Body	Driver Seat Module																			V																																						
T	2009	Envoy	Body	Generator Battery Control Module																																																									
T	2009	Envoy	Body	HVAC Control Module Auto																			V									V																														
T	2009	Envoy	Body	HVAC Control Module Manual																																																									
T	2009	Envoy	Body	Instrument Panel Cluster																																																									
T	2009	Envoy	Body	Lift Gate Module																																										V														
T	2009	Envoy	Body	Passenger Door Module																																																									
T	2009	Envoy	Body	Passenger Presence System																																																									
T	2009	Envoy	Body	Uplevel Radio																																																									
T	2009	Envoy	Body	Navigation Radio								V																																																	
T	2009	Envoy	Body	Rear Seat Audio																																																									
T	2009	Envoy	Body	Supplemental Inflatable Restraint	V																																																								
T	2009	Envoy	Body	Theft Deterrent Module		V																																																							
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																																V			V
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																			V
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module					V																																																V			V
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																									
T	2010	ALL	Chassis	Electronic Brake Control Module										V	V																																														
T	2010	ALL	Body	Body Control Module																																								V		V															
T	2010	ALL	Body	Digital Radio Receiver																																																									
T	2010	ALL	Body	Generator Battery Control Module																																																									
T	2010	ALL	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
T	2010	ALL	Body	Passenger Presence System																																																								
T	2010	ALL	Body	Personal Audio Link Module																																																								
T	2010	ALL	Body	Base Radio																																																								
T	2010	ALL	Body	Uplevel Radio																																																								
T	2010	ALL	Body	Supplemental Inflatable Restraint	V																																																								
T	2010	ALL	Body	Theft Deterrent Module		V																																																							
T	2010	ALL	Body	Vehicle Comm. Interface Module																																															V			V						
V	2007	ALL	Powertrain	Engine Control Module					V																																														V				V
V	2007	ALL	Powertrain	Rear Drive System																																																								
V	2007	ALL	Powertrain	Transmission Control Module																																																								
V	2007	ALL	Chassis	Electronic Brake Control Module													V																																											
V	2007	ALL	Body	Body Control Module			V																													V																									
V	2007	ALL	Body	Digital Radio Receiver																																																								
V	2007	ALL	Body	Driver Door Switch																																																								
V	2007	ALL	Body	Head Up Display																																																								
V	2007	ALL	Body	Heated Seat Module																																																								
V	2007	ALL	Body	HVAC Control Module Auto																																																								
V	2007	ALL	Body	HVAC Control Module Manual																																																								
V	2007	ALL	Body	Instrument Panel Cluster																																																								
V	2007	ALL	Body	Lift Gate Module																																																								
V	2007	ALL	Body	Park Assist Module																																																								
V	2007	ALL	Body	Passenger Door Switch																																																								
V	2007	ALL	Body	Passenger Presence System																																																								
V	2007	ALL	Body	Radio																																																								
V	2007	ALL	Body	Rear HVAC/RSA																																																								
V	2007	ALL	Body	Rollover Sensor																																																								
V	2007	ALL	Body	Supplemental Inflatable Restraint																			V																																						
V	2007	ALL	Body	Theft Deterrent Module		V																																																							
V	2008	ALL	Powertrain	Engine Control Module					V																																														V				V
V	2008	ALL	Powertrain	Rear Drive System																																																								
V	2008	ALL	Powertrain	Transmission Control Module																																																								
V	2008	ALL	Chassis	Electronic Brake Control Module													V																																											
V	2008	ALL	Body	Body Control Module			V																													V																									
V	2008	ALL	Body	Digital Radio Receiver																																																								
V	2008	ALL	Body	Driver Door Switch																																																								
V	2008	ALL	Body	Head Up Display																																																								
V	2008	ALL	Body	Heated Seat Module																																																								
V	2008	ALL	Body	HVAC Control Module Auto																																																								
V	2008	ALL	Body	HVAC Control Module Manual																																																								
V	2008	ALL	Body	Instrument Panel Cluster																																																								
V	2008	ALL	Body	Lift Gate Module																																																								
V	2008	ALL	Body	Park Assist Module																																																								
V	2008	ALL	Body	Passenger Door Switch																																																								
V	2008	ALL	Body	Passenger Presence System																																																								
V	2008	ALL	Body	Radio																																																								
V	2008	ALL	Body	Rear HVAC/RSA																																																								
V	2008	ALL	Body	Rollover Sensor																																																								
V	2008	ALL	Body	Supplemental Inflatable Restraint																			V																																						
V	2008	ALL	Body	Theft Deterrent Module		V																																																							
V	2009	ALL	Powertrain	Engine Control Module					V																																														V				V
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
V	2009	ALL	Powertrain	Rear Drive System																																																								
V	2009	ALL	Powertrain	Transmission Control Module																																																								
V	2009	ALL	Chassis	Electronic Brake Control Module													V																																											
V	2009	ALL	Body	Body Control Module			V																													V																									
V	2009	ALL	Body	Digital Radio Receiver																																																								
V	2009	ALL	Body	Driver Door Switch																																																								
V	2009	ALL	Body	Head Up Display																																																								
V	2009	ALL	Body	Heated Seat Module																																																								
V	2009	ALL	Body	HVAC Control Module Auto																																																								
V	2009	ALL	Body	HVAC Control Module Manual																																																								
V	2009	ALL	Body	Instrument Panel Cluster																																																								
V	2009	ALL	Body	Lift Gate Module																																																								
V	2009	ALL	Body	Park Assist Module																																																								
V	2009	ALL	Body	Passenger Door Switch																																																								
V	2009	ALL	Body	Passenger Presence System																																																								
V	2009	ALL	Body	Radio																																																								
V	2009	ALL	Body	Rear HVAC/RSA																																																								
V	2009	ALL	Body	Rollover Sensor																																																								
V	2009	ALL	Body	Supplemental Inflatable Restraint																			V																																					
V	2009	ALL	Body	Theft Deterrent Module		V																																																						
V	2010	ALL	Powertrain	Engine Control Module					V																																																			V
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2010	ALL	Powertrain	Rear Drive System																																																								
V	2010	ALL	Powertrain	Transmission Control Module																																																								
V	2010	ALL	Chassis	Electronic Brake Control Module													V																																											
V	2010	ALL	Body	Body Control Module			V																													V			V																						
V	2010	ALL	Body	Digital Radio Receiver																																																								
V	2010	ALL	Body	Driver Door Switch																																																								
V	2010	ALL	Body	Head Up Display																																																								
V	2010	ALL	Body	Heated Seat Module																																																								
V	2010	ALL	Body	HVAC Control Module Auto																																																								
V	2010	ALL	Body	HVAC Control Module Manual																																																								
V	2010	ALL	Body	Instrument Panel Cluster																																																								
V	2010	ALL	Body	Lift Gate Module																																																								
V	2010	ALL	Body	Park Assist Module																																																								
V	2010	ALL	Body	Passenger Door Switch																																																								
V	2010	ALL	Body	Passenger Presence System																																																								
V	2010	ALL	Body	Radio																																																								
V	2010	ALL	Body	Rear HVAC/RSA																																																								
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2010	ALL	Body	Theft Deterrent Module		V																																																						
V	2011	ALL	Powertrain	Engine Control Module					V																																																			V
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2011	ALL	Powertrain	Rear Drive System																																																								
V	2011	ALL	Powertrain	Transmission Control Module																																																								
V	2011	ALL	Chassis	Electronic Brake Control Module													V																																											
V	2011	ALL	Body	Body Control Module			V																													V			V																						
V	2011	ALL	Body	Digital Radio Receiver																																																								
V	2011	ALL	Body	Driver Door Switch																																																								
V	2011	ALL	Body	Head Up Display																																																								
V	2011	ALL	Body	Heated Seat Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
V	2011	ALL	Body	HVAC Control Module Auto																																																								
V	2011	ALL	Body	HVAC Control Module Manual																																																								
V	2011	ALL	Body	Instrument Panel Cluster																																																								
V	2011	ALL	Body	Lift Gate Module																																																								
V	2011	ALL	Body	Park Assist Module																																																								
V	2011	ALL	Body	Passenger Door Switch																																																								
V	2011	ALL	Body	Passenger Presence System																																																								
V	2011	ALL	Body	Radio																																																								
V	2011	ALL	Body	Rear HVAC/RSA																																																								
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2011	ALL	Body	Theft Deterrent Module		V																																																						
V	2012	ALL	Powertrain	Engine Control Module					V																																																			V
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2012	ALL	Powertrain	Rear Drive System																																																								
V	2012	ALL	Powertrain	Transmission Control Module																																																								
V	2012	ALL	Chassis	Electronic Brake Control Module													V																																											
V	2012	ALL	Body	Body Control Module			V																													V			V																					
V	2012	ALL	Body	Digital Radio Receiver																																																								
V	2012	ALL	Body	Driver Door Switch																																																								
V	2012	ALL	Body	Head Up Display																																																								
V	2012	ALL	Body	Heated Seat Module																																																								
V	2012	ALL	Body	HVAC Control Module Auto																																																								
V	2012	ALL	Body	HVAC Control Module Manual																																																								
V	2012	ALL	Body	Instrument Panel Cluster																																																								
V	2012	ALL	Body	Lift Gate Module																																																								
V	2012	ALL	Body	Park Assist Module																																																								
V	2012	ALL	Body	Passenger Door Switch																																																								
V	2012	ALL	Body	Passenger Presence System																																																								
V	2012	ALL	Body	Radio																																																								
V	2012	ALL	Body	Rear HVAC/RSA																																																								
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2012	ALL	Body	Theft Deterrent Module		V																																																						
V	2013	ALL	Powertrain	Engine Control Module					V																																																			V
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																								
V	2013	ALL	Powertrain	Rear Drive System																																																								
V	2013	ALL	Powertrain	Transmission Control Module																																																								
V	2013	ALL	Chassis	Electronic Brake Control Module													V																																											
V	2013	ALL	Body	Body Control Module			V																													V			V																					
V	2013	ALL	Body	Digital Radio Receiver																																																								
V	2013	ALL	Body	Driver Door Switch																																																								
V	2013	ALL	Body	Head Up Display																																																								
V	2013	ALL	Body	Heated Seat Module																																																								
V	2013	ALL	Body	HVAC Control Module Auto																																																								
V	2013	ALL	Body	HVAC Control Module Manual																																																								
V	2013	ALL	Body	Instrument Panel Cluster																																																								
V	2013	ALL	Body	Left Side Object Detection Module																																																								
V	2013	ALL	Body	Lift Gate Module																																																								
V	2013	ALL	Body	Park Assist Module																																																								
V	2013	ALL	Body	Passenger Door Switch																																																								
V	2013	ALL	Body	Passenger Presence System																																																								
V	2013	ALL	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
V	2013	ALL	Body	Rear HVAC/RSA																																																										
V	2013	ALL	Body	Right Side Object Detection Module																																																										
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2013	ALL	Body	Theft Deterrent Module		V																																																								
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2014	Acadia	Powertrain	Chassis Control Module																																																										
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
V	2014	Acadia	Chassis	Electronic Brake Control Module																																																										
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2014	Acadia	Body	Passenger Presence Module																																																										
V	2014	Acadia	Body	Instrument Cluster																																																										
V	2014	Acadia	Body	Head-Up Display Module																																																										
V	2014	Acadia	Body	Radio																																																										
V	2014	Acadia	Body	Rear Audio Control Module																																																										
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																										
V	2014	Acadia	Body	Personal Audio Link Control Module																																																										
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																										
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
V	2014	Acadia	Body	Liftgate Control Module																																																										
V	2014	Acadia	Body	Seat Memory Control Module																																																										
V	2014	Acadia	Body	Front Seat Heating Control Module																																																										
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																										
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																										
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																										
V	2014	Acadia	Body	Parking Assist Control Module																																																										
V	2014	Acadia	Body	Frontview Camera Module																																																										
V	2014	Acadia	Body	Theft Deterrent Module		V																																																								
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
V	2015	Acadia	Chassis	Electronic Brake Control Module																																																										
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Acadia	Body	Passenger Presence Module																																																										
V	2015	Acadia	Body	Instrument Cluster																																																										
V	2015	Acadia	Body	Head-Up Display Module																																																										
V	2015	Acadia	Body	Radio																																																										
V	2015	Acadia	Body	Rear Audio Control Module																																																										
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																										
V	2015	Acadia	Body	Personal Audio Link Control Module																																																										
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																									
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																										
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
V	2015	Acadia	Body	Liftgate Control Module																																																										
V	2015	Acadia	Body	Seat Memory Control Module																																																										
V	2015	Acadia	Body	Front Seat Heating Control Module																																																										
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																										
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																										
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																										
V	2015	Acadia	Body	Parking Assist Control Module																																																										
V	2015	Acadia	Body	Frontview Camera Module																																																										
V	2015	Acadia	Body	Theft Deterrent Module		V																																																								
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Acadia	Chassis	Electronic Brake Control Module																																																										
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Acadia	Body	Passenger Presence Module																																																										
V	2016	Acadia	Body	Instrument Cluster																																																										
V	2016	Acadia	Body	Head-Up Display Module																																																										
V	2016	Acadia	Body	Radio																																																										
V	2016	Acadia	Body	Rear Audio Control Module																																																										
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																										
V	2016	Acadia	Body	Personal Audio Link Control Module																																																										
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																										
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Acadia	Body	Liftgate Control Module																																																										
V	2016	Acadia	Body	Seat Memory Control Module																																																										
V	2016	Acadia	Body	Front Seat Heating Control Module																																																										
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																										
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																										
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																										
V	2016	Acadia	Body	Parking Assist Control Module																																																										
V	2016	Acadia	Body	Frontview Camera Module																																																										
V	2016	Acadia	Body	Theft Deterrent Module		V																																																								
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																																V			V
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V				
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																															V				
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V				
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																	V			V
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																V			
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																																V			
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module					V																																																V			
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES													V																																											
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES													V																																											
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																											
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																											
1	2011	Sierra	Chassis	Electronic Suspension Control																																																								
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																								
1	2011	Sierra	Body	Amplifier (Bose)																																																								
1	2011	Sierra	Body	Body Control Module			V																													V																									
1	2011	Sierra	Body	Body Control Module (aux.)																																																								
1	2011	Sierra	Body	Digital Radio Receiver																																																								
1	2011	Sierra	Body	Driver Door Switch																																																								
1	2011	Sierra	Body	HVAC Control Module Auto																																																								
1	2011	Sierra	Body	HVAC Control Module Manual																																																								
1	2011	Sierra	Body	Instrument Panel Cluster																																																								
1	2011	Sierra	Body	Memory Seat Module																					V	V																																		
1	2011	Sierra	Body	Park Assist Module																																																								
1	2011	Sierra	Body	Passenger Door Switch																																																								
1	2011	Sierra	Body	Passenger Presence System																																																								
1	2011	Sierra	Body	Radio																																																								
1	2011	Sierra	Body	Rear Heated Seat Module																																																								
1	2011	Sierra	Body	Rear HVAC/RSA																																																								
1	2011	Sierra	Body	Supplemental Inflatable Restraint																																																								
1	2011	Sierra	Body	Theft Deterrent Module		V																																																						
1	2011	Sierra Hybrid	Powertrain	Engine Control Module					V																																																V			
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																								
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																								
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																								
1	2011	Sierra Hybrid	Body	Body Control Module			V																													V																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																									
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																									
1	2011	Sierra Hybrid	Body	Driver Door Switch																																																									
1	2011	Sierra Hybrid	Body	Heated Seat Module																																																									
1	2011	Sierra Hybrid	Body	HVAC Control Module																																																									
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																									
1	2011	Sierra Hybrid	Body	Park Assist Module																																																									
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																																									
1	2011	Sierra Hybrid	Body	Passenger Presence System																																																									
1	2011	Sierra Hybrid	Body	Radio																																																									
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																									
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																									
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																									
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																									
1	2011	Sierra Hybrid	Body	Theft Deterrent Module		V																																																							
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V			
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																															V			
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2011	Yukon	Chassis	Electronic Brake Control Module													V																																											
1	2011	Yukon	Chassis	Electronic Suspension Control																																																									
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																									
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																									
1	2011	Yukon	Body	Amplifier (Bose)																																																									
1	2011	Yukon	Body	Assist Step Controller																																																									
1	2011	Yukon	Body	Body Control Module			V																													V																									
1	2011	Yukon	Body	Body Control Module (aux.)																																																									
1	2011	Yukon	Body	Digital Radio Receiver																																																									
1	2011	Yukon	Body	Driver Door Switch																																																									
1	2011	Yukon	Body	HVAC Control Module Auto																																																									
1	2011	Yukon	Body	HVAC Control Module Manual																																																									
1	2011	Yukon	Body	Instrument Panel Cluster																																																									
1	2011	Yukon	Body	Left Side Object Detection Module																																																									
1	2011	Yukon	Body	Lift Gate Module																																																									
1	2011	Yukon	Body	Memory Seat Module																					V	V																																			
1	2011	Yukon	Body	Park Assist Module																																																									
1	2011	Yukon	Body	Passenger Door Switch																																																									
1	2011	Yukon	Body	Passenger Presence System																																																									
1	2011	Yukon	Body	Radio																																																									
1	2011	Yukon	Body	Rear Heated Seat Module																																																									
1	2011	Yukon	Body	Rear HVAC/RSA																																																									
1	2011	Yukon	Body	Right Side Object Detection Module																																																									
1	2011	Yukon	Body	Supplemental Inflatable Restraint																																																									
1	2011	Yukon	Body	Theft Deterrent Module		V																																																							
1	2011	Yukon Hybrid	Powertrain	Engine Control Module					V																																																V			
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																									
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																									
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																									
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																									
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																									
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																									
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																									
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																									
1	2011	Yukon Hybrid	Body	Body Control Module			V																													V																									
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																									
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																									
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																									
1	2011	Yukon Hybrid	Body	HVAC Control Module																																																									
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																									
1	2011	Yukon Hybrid	Body	Lift Gate Module																																																									
1	2011	Yukon Hybrid	Body	Park Assist Module																																																									
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																									
1	2011	Yukon Hybrid	Body	Passenger Presence System																																																									
1	2011	Yukon Hybrid	Body	Radio																																																									
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
1	2011	Yukon Hybrid	Body	Theft Deterrent Module		V																																																							
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																V				
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V				
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																V				
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																V				
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW													V																																												
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																									
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																									
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
1	2011	Yukon XL	Body	Amplifier (Bose)																																																									
1	2011	Yukon XL	Body	Assist Step Controller																																																									
1	2011	Yukon XL	Body	Body Control Module			V																													V																									
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																									
1	2011	Yukon XL	Body	Digital Radio Receiver																																																									
1	2011	Yukon XL	Body	Driver Door Switch																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2011	Yukon XL	Body	HVAC Control Module Auto																																																								
1	2011	Yukon XL	Body	HVAC Control Module Manual																																																								
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																								
1	2011	Yukon XL	Body	Left Side Object Detection Module																																																								
1	2011	Yukon XL	Body	Lift Gate Module																																																								
1	2011	Yukon XL	Body	Memory Seat Module																					V	V																																		
1	2011	Yukon XL	Body	Park Assist Module																																																								
1	2011	Yukon XL	Body	Passenger Door Switch																																																								
1	2011	Yukon XL	Body	Passenger Presence System																																																								
1	2011	Yukon XL	Body	Radio																																																								
1	2011	Yukon XL	Body	Rear Heated Seat Module																																																								
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																								
1	2011	Yukon XL	Body	Right Side Object Detection Module																																																								
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
1	2011	Yukon XL	Body	Theft Deterrent Module		V																																																						
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V			V
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V			
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																															V			
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V			
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V			V
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																															V			
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																															V			
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module					V																																															V			
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES													V																																											
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES													V																																											
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																											
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																											
1	2012	Sierra	Chassis	Electronic Suspension Control																																																								
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																								
1	2012	Sierra	Body	Amplifier (Bose)																																																								
1	2012	Sierra	Body	Body Control Module			V																													V																								
1	2012	Sierra	Body	Body Control Module (aux.)																																																								
1	2012	Sierra	Body	Digital Radio Receiver																																																								
1	2012	Sierra	Body	Driver Door Switch																																																								
1	2012	Sierra	Body	HVAC Control Module Auto																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2012	Sierra	Body	HVAC Control Module Manual																																																								
1	2012	Sierra	Body	Instrument Panel Cluster																																																								
1	2012	Sierra	Body	Memory Seat Module																					V	V																																		
1	2012	Sierra	Body	Park Assist Module																																																							
1	2012	Sierra	Body	Passenger Door Switch																																																							
1	2012	Sierra	Body	Passenger Presence System																																																							
1	2012	Sierra	Body	Radio																																																							
1	2012	Sierra	Body	Navigation Radio																																																							
1	2012	Sierra	Body	Rear Heated Seat Module																																																							
1	2012	Sierra	Body	Rear HVAC/RSA																																																							
1	2012	Sierra	Body	Supplemental Inflatable Restraint																																																							
1	2012	Sierra	Body	Theft Deterrent Module		V																																																						
1	2012	Sierra Hybrid	Powertrain	Engine Control Module					V																																															V			
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																							
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																							
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																							
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																							
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																							
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																							
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																							
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																							
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																							
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																							
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																							
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																							
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																							
1	2012	Sierra Hybrid	Body	Body Control Module			V																													V																								
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																							
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																							
1	2012	Sierra Hybrid	Body	Driver Door Switch																																																							
1	2012	Sierra Hybrid	Body	Heated Seat Module																																																							
1	2012	Sierra Hybrid	Body	HVAC Control Module																																																							
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																							
1	2012	Sierra Hybrid	Body	Park Assist Module																																																							
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																																							
1	2012	Sierra Hybrid	Body	Passenger Presence System																																																							
1	2012	Sierra Hybrid	Body	Radio																																																							
1	2012	Sierra Hybrid	Body	Navigation Radio																																																							
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																							
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																							
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																							
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																							
1	2012	Sierra Hybrid	Body	Theft Deterrent Module		V																																																					
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V			
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																							
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																														V			
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																							
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																							
1	2012	Yukon	Chassis	Electronic Brake Control Module													V																																										
1	2012	Yukon	Chassis	Electronic Suspension Control																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																								
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
1	2012	Yukon	Body	Amplifier (Bose)																																																								
1	2012	Yukon	Body	Assist Step Controller																																																								
1	2012	Yukon	Body	Body Control Module			V																													V			V																						
1	2012	Yukon	Body	Body Control Module (aux.)																																																								
1	2012	Yukon	Body	Digital Radio Receiver																																																								
1	2012	Yukon	Body	Driver Door Switch																																																								
1	2012	Yukon	Body	HVAC Control Module Auto																																																								
1	2012	Yukon	Body	HVAC Control Module Manual																																																								
1	2012	Yukon	Body	Instrument Panel Cluster																																																								
1	2012	Yukon	Body	Left Side Object Detection Module																																																								
1	2012	Yukon	Body	Lift Gate Module																																																								
1	2012	Yukon	Body	Memory Seat Module																					V	V																																			
1	2012	Yukon	Body	Park Assist Module																																																								
1	2012	Yukon	Body	Passenger Door Switch																																																								
1	2012	Yukon	Body	Passenger Presence System																																																								
1	2012	Yukon	Body	Radio																																																								
1	2012	Yukon	Body	Navigation Radio																																																								
1	2012	Yukon	Body	Rear Heated Seat Module																																																								
1	2012	Yukon	Body	Rear HVAC/RSA																																																								
1	2012	Yukon	Body	Right Side Object Detection Module																																																								
1	2012	Yukon	Body	Supplemental Inflatable Restraint																																																								
1	2012	Yukon	Body	Theft Deterrent Module		V																																																						
1	2012	Yukon Hybrid	Powertrain	Engine Control Module					V																																															V				
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																								
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																								
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																								
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																								
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																								
1	2012	Yukon Hybrid	Body	Body Control Module			V																													V			V																						
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																								
1	2012	Yukon Hybrid	Body	Driver Door Switch																																																								
1	2012	Yukon Hybrid	Body	Heated Seat Module																																																								
1	2012	Yukon Hybrid	Body	HVAC Control Module																																																								
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
1	2012	Yukon Hybrid	Body	Lift Gate Module																																																								
1	2012	Yukon Hybrid	Body	Park Assist Module																																																								
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																																								
1	2012	Yukon Hybrid	Body	Passenger Presence System																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2012	Yukon Hybrid	Body	Radio																																																									
1	2012	Yukon Hybrid	Body	Navigation Radio																																																									
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
1	2012	Yukon Hybrid	Body	Theft Deterrent Module		V																																																							
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																																V				
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V				
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																V				
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																V				
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW													V																																												
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																									
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																									
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
1	2012	Yukon XL	Body	Amplifier (Bose)																																																									
1	2012	Yukon XL	Body	Assist Step Controller																																																									
1	2012	Yukon XL	Body	Body Control Module			V																													V			V																						
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																									
1	2012	Yukon XL	Body	Digital Radio Receiver																																																									
1	2012	Yukon XL	Body	Driver Door Switch																																																									
1	2012	Yukon XL	Body	HVAC Control Module Auto																																																									
1	2012	Yukon XL	Body	HVAC Control Module Manual																																																									
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																									
1	2012	Yukon XL	Body	Left Side Object Detection Module																																																									
1	2012	Yukon XL	Body	Lift Gate Module																																																									
1	2012	Yukon XL	Body	Memory Seat Module																					V	V																																			
1	2012	Yukon XL	Body	Park Assist Module																																																									
1	2012	Yukon XL	Body	Passenger Door Switch																																																									
1	2012	Yukon XL	Body	Passenger Presence System																																																									
1	2012	Yukon XL	Body	Radio																																																									
1	2012	Yukon XL	Body	Navigation Radio																																																									
1	2012	Yukon XL	Body	Rear Heated Seat Module																																																									
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																									
1	2012	Yukon XL	Body	Right Side Object Detection Module																																																									
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
1	2012	Yukon XL	Body	Theft Deterrent Module		V																																																							
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																																V				V
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																																V				
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																																			
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																			
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																			V
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																																			V
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																								
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																			
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module					V																																																			
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES													V																																										
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES													V																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES													V																																										
1	2013	Sierra	Chassis	Electronic Suspension Control																																																								
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Sierra	Body	Amplifier (Bose)																																																								
1	2013	Sierra	Body	Body Control Module			V																													V			V																					
1	2013	Sierra	Body	Body Control Module (aux.)																																																								
1	2013	Sierra	Body	Digital Radio Receiver																																																								
1	2013	Sierra	Body	Driver Door Switch																																																								
1	2013	Sierra	Body	HVAC Control Module Auto																																																								
1	2013	Sierra	Body	HVAC Control Module Manual																																																								
1	2013	Sierra	Body	Instrument Panel Cluster																																																								
1	2013	Sierra	Body	Memory Seat Module																					V	V																																		
1	2013	Sierra	Body	Park Assist Module																																																								
1	2013	Sierra	Body	Passenger Door Switch																																																								
1	2013	Sierra	Body	Passenger Presence System																																																								
1	2013	Sierra	Body	Radio																																																								
1	2013	Sierra	Body	Navigation Radio																																																								
1	2013	Sierra	Body	Rear Heated Seat Module																																																								
1	2013	Sierra	Body	Rear HVAC/RSA																																																								
1	2013	Sierra	Body	Supplemental Inflatable Restraint																																																								
1	2013	Sierra	Body	Theft Deterrent Module		V																																																						
1	2013	Sierra Hybrid	Powertrain	Engine Control Module					V																																																			
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																								
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																								
1	2013	Sierra Hybrid	Body	Body Control Module			V																												V			V																						
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																								
1	2013	Sierra Hybrid	Body	Driver Door Switch																																																								
1	2013	Sierra Hybrid	Body	Heated Seat Module																																																								
1	2013	Sierra Hybrid	Body	HVAC Control Module																																																								
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
1	2013	Sierra Hybrid	Body	Park Assist Module																																																								
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																																								
1	2013	Sierra Hybrid	Body	Passenger Presence System																																																								
1	2013	Sierra Hybrid	Body	Radio																																																								
1	2013	Sierra Hybrid	Body	Navigation Radio																																																								
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
1	2013	Sierra Hybrid	Body	Theft Deterrent Module		V																																																						
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V				
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																														V				
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
1	2013	Yukon	Chassis	Electronic Brake Control Module													V																																										
1	2013	Yukon	Chassis	Electronic Suspension Control																																																								
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Yukon	Body	Amplifier (Bose)																																																								
1	2013	Yukon	Body	Assist Step Controller																																																								
1	2013	Yukon	Body	Body Control Module			V																												V			V																						
1	2013	Yukon	Body	Body Control Module (aux.)																																																								
1	2013	Yukon	Body	Digital Radio Receiver																																																								
1	2013	Yukon	Body	Driver Door Switch																																																								
1	2013	Yukon	Body	HVAC Control Module Auto																																																								
1	2013	Yukon	Body	HVAC Control Module Manual																																																								
1	2013	Yukon	Body	Instrument Panel Cluster																																																								
1	2013	Yukon	Body	Left Side Object Detection Module																																																								
1	2013	Yukon	Body	Lift Gate Module																																																								
1	2013	Yukon	Body	Memory Seat Module																					V	V																																		
1	2013	Yukon	Body	Park Assist Module																																																								
1	2013	Yukon	Body	Passenger Door Switch																																																								
1	2013	Yukon	Body	Passenger Presence System																																																								
1	2013	Yukon	Body	Radio																																																								
1	2013	Yukon	Body	Navigation Radio																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2013	Yukon	Body	Rear Heated Seat Module																																																								
1	2013	Yukon	Body	Rear HVAC/RSA																																																								
1	2013	Yukon	Body	Right Side Object Detection Module																																																								
1	2013	Yukon	Body	Supplemental Inflatable Restraint																																																								
1	2013	Yukon	Body	Theft Deterrent Module		V																																																						
1	2013	Yukon Hybrid	Powertrain	Engine Control Module					V																																															V				
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																								
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																								
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																								
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																								
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																								
1	2013	Yukon Hybrid	Body	Body Control Module			V																													V			V																					
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																								
1	2013	Yukon Hybrid	Body	Driver Door Switch																																																								
1	2013	Yukon Hybrid	Body	Heated Seat Module																																																								
1	2013	Yukon Hybrid	Body	HVAC Control Module																																																								
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
1	2013	Yukon Hybrid	Body	Lift Gate Module																																																								
1	2013	Yukon Hybrid	Body	Park Assist Module																																																								
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																																								
1	2013	Yukon Hybrid	Body	Passenger Presence System																																																								
1	2013	Yukon Hybrid	Body	Radio																																																								
1	2013	Yukon Hybrid	Body	Navigation Radio																																																								
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																								
1	2013	Yukon Hybrid	Body	Theft Deterrent Module		V																																																						
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																															V				
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V				
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V				
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																															V				
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW													V																																												
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																									
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Yukon XL	Body	Amplifier (Bose)																																																									
1	2013	Yukon XL	Body	Assist Step Controller																																																									
1	2013	Yukon XL	Body	Body Control Module			V																													V			V																						
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																									
1	2013	Yukon XL	Body	Digital Radio Receiver																																																									
1	2013	Yukon XL	Body	Driver Door Switch																																																									
1	2013	Yukon XL	Body	HVAC Control Module Auto																																																									
1	2013	Yukon XL	Body	HVAC Control Module Manual																																																									
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																									
1	2013	Yukon XL	Body	Left Side Object Detection Module																																																									
1	2013	Yukon XL	Body	Lift Gate Module																																																									
1	2013	Yukon XL	Body	Memory Seat Module																					V	V																																			
1	2013	Yukon XL	Body	Park Assist Module																																																									
1	2013	Yukon XL	Body	Passenger Door Switch																																																									
1	2013	Yukon XL	Body	Passenger Presence System																																																									
1	2013	Yukon XL	Body	Radio																																																									
1	2013	Yukon XL	Body	Navigation Radio																																																									
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																									
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																									
1	2013	Yukon XL	Body	Right Side Object Detection Module																																																									
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
1	2013	Yukon XL	Body	Theft Deterrent Module		V																																																							
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																									
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2014	Sierra	Chassis	Electronic Brake Control Module																																																									
1	2014	Sierra	Chassis	Parking Brake Control Module																																																									
1	2014	Sierra	Chassis	Power Steering Control Module																																																									
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2014	Sierra	Body	Body Control Module																																																									
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2014	Sierra	Body	Passenger Presence Module																																																									
1	2014	Sierra	Body	Instrument Cluster																																																									
1	2014	Sierra	Body	Radio Control																																																									
1	2014	Sierra	Body	HVAC Control																																																									
1	2014	Sierra	Body	Radio																																																									
1	2014	Sierra	Body	Amplifier																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2014	Sierra	Body	Media Disc Player																																																												
1	2014	Sierra	Body	Human Machine Interface Control Module																																																												
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
1	2014	Sierra	Body	Parking Assist Control Module																																																												
1	2014	Sierra	Body	Frontview Camera Module																																																												
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																												
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																												
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																												
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																												
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																												
1	2014	Sierra HD	Chassis	Suspension Control Module																																																												
1	2014	Sierra HD	Body	Body Control Module																																																												
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	Sierra HD	Body	Instrument Cluster																																																												
1	2014	Sierra HD	Body	Base Radio																																																												
1	2014	Sierra HD	Body	Navigation Radio																																																												
1	2014	Sierra HD	Body	Uplevel Radio																																																												
1	2014	Sierra HD	Body	Amplifier																																																												
1	2014	Sierra HD	Body	Rear Audio Control Module																																																												
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																												
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																												
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																												
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																												
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																												
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																												
1	2014	Sierra HD	Body	Seat Memory Control Module																																																												
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																												
1	2014	Sierra HD	Body	Parking Assist Control Module																																																												
1	2014	Sierra HD	Body	Theft Deterrent Module		V																																																										
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																												
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2014	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2014	Yukon	Chassis	Parking Brake Control Module																																																										
1	2014	Yukon	Chassis	Suspension Control Module																																																										
1	2014	Yukon	Body	Body Control Module																																																										
1	2014	Yukon	Body	Auxiliary Body Control Module																																																										
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Yukon	Body	Passenger Presence Module																																																										
1	2014	Yukon	Body	Instrument Cluster																																																										
1	2014	Yukon	Body	Base Radio																																																										
1	2014	Yukon	Body	Navigation Radio																																																										
1	2014	Yukon	Body	Uplevel Radio																																																										
1	2014	Yukon	Body	Amplifier																																																										
1	2014	Yukon	Body	Rear Audio Control Module																																																										
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																																										
1	2014	Yukon	Body	Personal Audio Link Control Module																																																										
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Yukon	Body	Liftgate Control Module																																																										
1	2014	Yukon	Body	Seat Memory Control Module																																																										
1	2014	Yukon	Body	Rear Seat Heating Control Module																																																										
1	2014	Yukon	Body	Assist Step Control Module																																																										
1	2014	Yukon	Body	Right Side Object Detection Control Module																																																										
1	2014	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																																										
1	2014	Yukon	Body	Parking Assist Control Module																																																										
1	2014	Yukon	Body	Theft Deterrent Module		V																																																								
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																										
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2014	Yukon XL	Chassis	Suspension Control Module																																																										
1	2014	Yukon XL	Body	Body Control Module																																																										
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																																										
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Yukon XL	Body	Passenger Presence Module																																																										
1	2014	Yukon XL	Body	Instrument Cluster																																																										
1	2014	Yukon XL	Body	Base Radio																																																										
1	2014	Yukon XL	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2014	Yukon XL	Body	Uplevel Radio																																																									
1	2014	Yukon XL	Body	Amplifier																																																									
1	2014	Yukon XL	Body	Rear Audio Control Module																																																									
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																									
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																																									
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																									
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																									
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																									
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																									
1	2014	Yukon XL	Body	Liftgate Control Module																																																									
1	2014	Yukon XL	Body	Seat Memory Control Module																																																									
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																									
1	2014	Yukon XL	Body	Assist Step Control Module																																																									
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																									
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																									
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																									
1	2014	Yukon XL	Body	Parking Assist Control Module																																																									
1	2014	Yukon XL	Body	Theft Deterrent Module		V																																																							
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2015	Sierra	Chassis	Electronic Brake Control Module																																																									
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																									
1	2015	Sierra	Chassis	Power Steering Control Module																																																									
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2015	Sierra	Chassis	Suspension Control Module																																																									
1	2015	Sierra	Body	Body Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Sierra	Body	Passenger Presence Module																																																											
1	2015	Sierra	Body	Instrument Cluster																																																											
1	2015	Sierra	Body	Radio Controls																																																											
1	2015	Sierra	Body	HVAC Controls																																																											
1	2015	Sierra	Body	Radio																																																											
1	2015	Sierra	Body	Amplifier																																																											
1	2015	Sierra	Body	Media Disc Player																																																											
1	2015	Sierra	Body	Human Machine Interface Control Module																																																											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
1	2015	Sierra	Body	Parking Assist Control Module																																																											
1	2015	Sierra	Body	Frontview Camera Module																																																											
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																											
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																											
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																											
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																											
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																											
1	2015	Yukon	Chassis	Electronic Brake Control Module																																																											
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																											
1	2015	Yukon	Chassis	Parking Brake Control Module																																																											
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2015	Yukon	Chassis	Power Steering Control Module																																																											
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2015	Yukon	Chassis	Suspension Control Module																																																											
1	2015	Yukon	Body	Body Control Module																																																											
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	Yukon	Body	Passenger Presence Module																																																											
1	2015	Yukon	Body	Instrument Cluster																																																											
1	2015	Yukon	Body	Radio Controls																																																											
1	2015	Yukon	Body	HVAC Controls																																																											
1	2015	Yukon	Body	Radio																																																											
1	2015	Yukon	Body	Amplifier																																																											
1	2015	Yukon	Body	Media Disc Player																																																											
1	2015	Yukon	Body	Human Machine Interface Control Module																																																											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2015	Yukon	Body	HVAC Control Module																																																									
1	2015	Yukon	Body	Liftgate Control Module																																																										
1	2015	Yukon	Body	Keyless Entry Control Module																																																										
1	2015	Yukon	Body	Assist Step Control Module																																																										
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon	Body	Parking Assist Control Module																																																										
1	2015	Yukon	Body	Frontview Camera Module																																																										
1	2015	Yukon	Body	Steering Column Lock Control Module																																																										
1	2015	Yukon	Body	Battery Energy Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	Yukon XL	Chassis	Power Steering Control Module																																																										
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Yukon XL	Chassis	Suspension Control Module																																																										
1	2015	Yukon XL	Body	Body Control Module																																																										
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Yukon XL	Body	Passenger Presence Module																																																										
1	2015	Yukon XL	Body	Instrument Cluster																																																										
1	2015	Yukon XL	Body	Radio Controls																																																										
1	2015	Yukon XL	Body	HVAC Controls																																																										
1	2015	Yukon XL	Body	Radio																																																										
1	2015	Yukon XL	Body	Amplifier																																																										
1	2015	Yukon XL	Body	Media Disc Player																																																										
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Yukon XL	Body	HVAC Control Module																																																										
1	2015	Yukon XL	Body	Liftgate Control Module																																																										
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
1	2015	Yukon XL	Body	Assist Step Control Module																																																										
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon XL	Body	Parking Assist Control Module																																																										
1	2015	Yukon XL	Body	Frontview Camera Module																																																										
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2016	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Sierra	Chassis	Parking Brake Control Module																																																										
1	2016	Sierra	Chassis	Power Steering Control Module																																																										
1	2016	Sierra	Chassis	Power Steering Control Module																																																										
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Sierra	Chassis	Suspension Control Module																																																										
1	2016	Sierra	Body	Body Control Module																																																										
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Sierra	Body	Passenger Presence Module																																																										
1	2016	Sierra	Body	Instrument Cluster																																																										
1	2016	Sierra	Body	Radio Controls																																																										
1	2016	Sierra	Body	HVAC Controls																																																										
1	2016	Sierra	Body	Radio (IO3)																																																										
1	2016	Sierra	Body	Radio (IOB)																																																										
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
1	2016	Sierra	Body	Amplifier																																																										
1	2016	Sierra	Body	Media Disc Player																																																										
1	2016	Sierra	Body	Human Machine Interface Control Module																																																										
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																										
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																										
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																										
1	2016	Sierra	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2016	Sierra	Body	Frontview Camera Module																																																									
1	2016	Sierra	Body	Frontview Camera Module																																																									
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2016	Yukon	Chassis	Electronic Brake Control Module																																																									
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																									
1	2016	Yukon	Chassis	Parking Brake Control Module																																																									
1	2016	Yukon	Chassis	Power Steering Control Module																																																									
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2016	Yukon	Chassis	Suspension Control Module																																																									
1	2016	Yukon	Body	Body Control Module																																																									
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2016	Yukon	Body	Passenger Presence Module																																																									
1	2016	Yukon	Body	Instrument Cluster																																																									
1	2016	Yukon	Body	Radio Controls																																																									
1	2016	Yukon	Body	HVAC Controls																																																									
1	2016	Yukon	Body	Radio																																																									
1	2016	Yukon	Body	Amplifier																																																									
1	2016	Yukon	Body	Media Disc Player																																																									
1	2016	Yukon	Body	Human Machine Interface Control Module																																																									
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																									
1	2016	Yukon	Body	HVAC Control Module																																																									
1	2016	Yukon	Body	Liftgate Control Module																																																									
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																									
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																									
1	2016	Yukon	Body	Keyless Entry Control Module																																																									
1	2016	Yukon	Body	Assist Step Control Module																																																									
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																									
1	2016	Yukon	Body	Parking Assist Control Module																																																									
1	2016	Yukon	Body	Frontview Camera Module																																																									
1	2016	Yukon	Body	Steering Column Lock Control Module																																																									
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																									
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																									
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																									
1	2016	Yukon XL	Chassis	Power Steering Control Module																																																									
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2016	Yukon XL	Chassis	Suspension Control Module																																																									
1	2016	Yukon XL	Body	Body Control Module																																																									
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
1	2016	Yukon XL	Body	Passenger Presence Module																																																								
1	2016	Yukon XL	Body	Instrument Cluster																																																								
1	2016	Yukon XL	Body	Radio Controls																																																								
1	2016	Yukon XL	Body	HVAC Controls																																																								
1	2016	Yukon XL	Body	Radio																																																								
1	2016	Yukon XL	Body	Amplifier																																																								
1	2016	Yukon XL	Body	Media Disc Player																																																								
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																								
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																								
1	2016	Yukon XL	Body	HVAC Control Module																																																								
1	2016	Yukon XL	Body	Liftgate Control Module																																																								
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																								
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																								
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																								
1	2016	Yukon XL	Body	Assist Step Control Module																																																								
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																								
1	2016	Yukon XL	Body	Parking Assist Control Module																																																								
1	2016	Yukon XL	Body	Frontview Camera Module																																																								
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																								
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V			V
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V			
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																															V			
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V			
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V			V
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																															V			
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																															V			
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module					V																																															V			
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES													V																																													
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES													V																																													
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																													
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																													
2	2011	Sierra	Chassis	Electronic Suspension Control																																																											
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																											
2	2011	Sierra	Body	Amplifier (Bose)																																																											
2	2011	Sierra	Body	Body Control Module			V																													V																											
2	2011	Sierra	Body	Body Control Module (aux.)																																																											
2	2011	Sierra	Body	Digital Radio Receiver																																																											
2	2011	Sierra	Body	Driver Door Switch																																																											
2	2011	Sierra	Body	HVAC Control Module Auto																																																											
2	2011	Sierra	Body	HVAC Control Module Manual																																																											
2	2011	Sierra	Body	Instrument Panel Cluster																																																											
2	2011	Sierra	Body	Memory Seat Module																					V	V																																						
2	2011	Sierra	Body	Park Assist Module																																																											
2	2011	Sierra	Body	Passenger Door Switch																																																											
2	2011	Sierra	Body	Passenger Presence System																																																											
2	2011	Sierra	Body	Radio																																																											
2	2011	Sierra	Body	Rear Heated Seat Module																																																											
2	2011	Sierra	Body	Rear HVAC/RSA																																																											
2	2011	Sierra	Body	Supplemental Inflatable Restraint																																																											
2	2011	Sierra	Body	Theft Deterrent Module		V																																																									
2	2011	Sierra Hybrid	Powertrain	Engine Control Module					V																																																V				
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																											
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																											
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																											
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																											
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																											
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																											
2	2011	Sierra Hybrid	Body	Body Control Module			V																													V																											
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																											
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																											
2	2011	Sierra Hybrid	Body	Driver Door Switch																																																											
2	2011	Sierra Hybrid	Body	Heated Seat Module																																																											
2	2011	Sierra Hybrid	Body	HVAC Control Module																																																											
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																											
2	2011	Sierra Hybrid	Body	Park Assist Module																																																											
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																																											
2	2011	Sierra Hybrid	Body	Passenger Presence System																																																											
2	2011	Sierra Hybrid	Body	Radio																																																											
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																											
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2011	Sierra Hybrid	Body	Theft Deterrent Module		V																																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V					
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																V					
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2011	Yukon	Chassis	Electronic Brake Control Module													V																																													
2	2011	Yukon	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																										
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon	Body	Amplifier (Bose)																																																										
2	2011	Yukon	Body	Assist Step Controller																																																										
2	2011	Yukon	Body	Body Control Module			V																													V																										
2	2011	Yukon	Body	Body Control Module (aux.)																																																										
2	2011	Yukon	Body	Digital Radio Receiver																																																										
2	2011	Yukon	Body	Driver Door Switch																																																										
2	2011	Yukon	Body	HVAC Control Module Auto																																																										
2	2011	Yukon	Body	HVAC Control Module Manual																																																										
2	2011	Yukon	Body	Instrument Panel Cluster																																																										
2	2011	Yukon	Body	Left Side Object Detection Module																																																										
2	2011	Yukon	Body	Lift Gate Module																																																										
2	2011	Yukon	Body	Memory Seat Module																					V	V																																				
2	2011	Yukon	Body	Park Assist Module																																																										
2	2011	Yukon	Body	Passenger Door Switch																																																										
2	2011	Yukon	Body	Passenger Presence System																																																										
2	2011	Yukon	Body	Radio																																																										
2	2011	Yukon	Body	Rear Heated Seat Module																																																										
2	2011	Yukon	Body	Rear HVAC/RSA																																																										
2	2011	Yukon	Body	Right Side Object Detection Module																																																										
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2011	Yukon	Body	Theft Deterrent Module		V																																																								
2	2011	Yukon Hybrid	Powertrain	Engine Control Module					V																																																V					
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2011	Yukon Hybrid	Body	Body Control Module			V																													V																										
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2011	Yukon Hybrid	Body	Driver Door Switch																																																										
2	2011	Yukon Hybrid	Body	Heated Seat Module																																																										
2	2011	Yukon Hybrid	Body	HVAC Control Module																																																										
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
2	2011	Yukon Hybrid	Body	Lift Gate Module																																																										
2	2011	Yukon Hybrid	Body	Park Assist Module																																																										
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																																										
2	2011	Yukon Hybrid	Body	Passenger Presence System																																																										
2	2011	Yukon Hybrid	Body	Radio																																																										
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2011	Yukon Hybrid	Body	Theft Deterrent Module		V																																																								
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module					V																																																	V			
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V			
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																V			
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																V			
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW													V																																												
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																										
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon XL	Body	Amplifier (Bose)																																																										
2	2011	Yukon XL	Body	Assist Step Controller																																																										
2	2011	Yukon XL	Body	Body Control Module			V																													V																										
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																										
2	2011	Yukon XL	Body	Digital Radio Receiver																																																										
2	2011	Yukon XL	Body	Driver Door Switch																																																										
2	2011	Yukon XL	Body	HVAC Control Module Auto																																																										
2	2011	Yukon XL	Body	HVAC Control Module Manual																																																										
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																										
2	2011	Yukon XL	Body	Left Side Object Detection Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2011	Yukon XL	Body	Lift Gate Module																																																								
2	2011	Yukon XL	Body	Memory Seat Module																					V	V																																			
2	2011	Yukon XL	Body	Park Assist Module																																																								
2	2011	Yukon XL	Body	Passenger Door Switch																																																								
2	2011	Yukon XL	Body	Passenger Presence System																																																								
2	2011	Yukon XL	Body	Radio																																																								
2	2011	Yukon XL	Body	Rear Heated Seat Module																																																								
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																								
2	2011	Yukon XL	Body	Right Side Object Detection Module																																																								
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
2	2011	Yukon XL	Body	Theft Deterrent Module		V																																																							
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V			V
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																														V				
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																														V				
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																														V				
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																														V				V
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																														V				
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																														V				
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module					V																																														V				
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES													V																																											
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES													V																																											
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																											
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES													V																																											
2	2012	Sierra	Chassis	Electronic Suspension Control																																																								
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																								
2	2012	Sierra	Body	Amplifier (Bose)																																																								
2	2012	Sierra	Body	Body Control Module			V																													V																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2012	Sierra	Body	Body Control Module (aux.)																																																									
2	2012	Sierra	Body	Digital Radio Receiver																																																									
2	2012	Sierra	Body	Driver Door Switch																																																									
2	2012	Sierra	Body	HVAC Control Module Auto																																																									
2	2012	Sierra	Body	HVAC Control Module Manual																																																									
2	2012	Sierra	Body	Instrument Panel Cluster																																																									
2	2012	Sierra	Body	Memory Seat Module																					V	V																																				
2	2012	Sierra	Body	Park Assist Module																																																									
2	2012	Sierra	Body	Passenger Door Switch																																																									
2	2012	Sierra	Body	Passenger Presence System																																																									
2	2012	Sierra	Body	Radio																																																									
2	2012	Sierra	Body	Navigation Radio																																																									
2	2012	Sierra	Body	Rear Heated Seat Module																																																									
2	2012	Sierra	Body	Rear HVAC/RSA																																																									
2	2012	Sierra	Body	Supplemental Inflatable Restraint																																																									
2	2012	Sierra	Body	Theft Deterrent Module		V																																																							
2	2012	Sierra Hybrid	Powertrain	Engine Control Module					V																																																V				
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																									
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																									
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																									
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																									
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																									
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																									
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																									
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																									
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																									
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																									
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																									
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																									
2	2012	Sierra Hybrid	Body	Body Control Module			V																													V																										
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																									
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																									
2	2012	Sierra Hybrid	Body	Driver Door Switch																																																									
2	2012	Sierra Hybrid	Body	Heated Seat Module																																																									
2	2012	Sierra Hybrid	Body	HVAC Control Module																																																									
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																									
2	2012	Sierra Hybrid	Body	Park Assist Module																																																									
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																																									
2	2012	Sierra Hybrid	Body	Passenger Presence System																																																									
2	2012	Sierra Hybrid	Body	Radio																																																									
2	2012	Sierra Hybrid	Body	Navigation Radio																																																									
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																									
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																									
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																									
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																									
2	2012	Sierra Hybrid	Body	Theft Deterrent Module		V																																																							
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V				
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																								
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																							
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																														V			
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																							
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																							
2	2012	Yukon	Chassis	Electronic Brake Control Module													V																																										
2	2012	Yukon	Chassis	Electronic Suspension Control																																																							
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																							
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																							
2	2012	Yukon	Body	Amplifier (Bose)																																																							
2	2012	Yukon	Body	Assist Step Controller																																																							
2	2012	Yukon	Body	Body Control Module			V																												V			V																						
2	2012	Yukon	Body	Body Control Module (aux.)																																																							
2	2012	Yukon	Body	Digital Radio Receiver																																																							
2	2012	Yukon	Body	Driver Door Switch																																																							
2	2012	Yukon	Body	HVAC Control Module Auto																																																							
2	2012	Yukon	Body	HVAC Control Module Manual																																																							
2	2012	Yukon	Body	Instrument Panel Cluster																																																							
2	2012	Yukon	Body	Left Side Object Detection Module																																																							
2	2012	Yukon	Body	Lift Gate Module																																																							
2	2012	Yukon	Body	Memory Seat Module																					V	V																																		
2	2012	Yukon	Body	Park Assist Module																																																							
2	2012	Yukon	Body	Passenger Door Switch																																																							
2	2012	Yukon	Body	Passenger Presence System																																																							
2	2012	Yukon	Body	Radio																																																							
2	2012	Yukon	Body	Navigation Radio																																																							
2	2012	Yukon	Body	Rear Heated Seat Module																																																							
2	2012	Yukon	Body	Rear HVAC/RSA																																																							
2	2012	Yukon	Body	Right Side Object Detection Module																																																							
2	2012	Yukon	Body	Supplemental Inflatable Restraint																																																							
2	2012	Yukon	Body	Theft Deterrent Module		V																																																					
2	2012	Yukon Hybrid	Powertrain	Engine Control Module					V																																														V			
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																							
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																							
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																							
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																							
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																							
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																							
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																							
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																							
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																							
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																							
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																							
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																							
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																							
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																							
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																							
2	2012	Yukon Hybrid	Body	Body Control Module			V																												V			V																						
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																							
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																							
2	2012	Yukon Hybrid	Body	Driver Door Switch																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2012	Yukon Hybrid	Body	Heated Seat Module																																																								
2	2012	Yukon Hybrid	Body	HVAC Control Module																																																								
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
2	2012	Yukon Hybrid	Body	Lift Gate Module																																																								
2	2012	Yukon Hybrid	Body	Park Assist Module																																																								
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																																								
2	2012	Yukon Hybrid	Body	Passenger Presence System																																																								
2	2012	Yukon Hybrid	Body	Radio																																																								
2	2012	Yukon Hybrid	Body	Navigation Radio																																																								
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																								
2	2012	Yukon Hybrid	Body	Theft Deterrent Module		V																																																						
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																																V			
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																V			
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																								
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																V			
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																V			
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																								
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW													V																																											
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW													V																																											
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																								
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																								
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
2	2012	Yukon XL	Body	Amplifier (Bose)																																																								
2	2012	Yukon XL	Body	Assist Step Controller																																																								
2	2012	Yukon XL	Body	Body Control Module			V																													V			V																					
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																								
2	2012	Yukon XL	Body	Digital Radio Receiver																																																								
2	2012	Yukon XL	Body	Driver Door Switch																																																								
2	2012	Yukon XL	Body	HVAC Control Module Auto																																																								
2	2012	Yukon XL	Body	HVAC Control Module Manual																																																								
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																								
2	2012	Yukon XL	Body	Left Side Object Detection Module																																																								
2	2012	Yukon XL	Body	Lift Gate Module																																																								
2	2012	Yukon XL	Body	Memory Seat Module																					V	V																																		
2	2012	Yukon XL	Body	Park Assist Module																																																								
2	2012	Yukon XL	Body	Passenger Door Switch																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2012	Yukon XL	Body	Passenger Presence System																																																								
2	2012	Yukon XL	Body	Radio																																																								
2	2012	Yukon XL	Body	Navigation Radio																																																								
2	2012	Yukon XL	Body	Rear Heated Seat Module																																																								
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																								
2	2012	Yukon XL	Body	Right Side Object Detection Module																																																								
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
2	2012	Yukon XL	Body	Theft Deterrent Module		V																																																						
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V			V
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V				
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																															V				
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V				
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V			V	
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																															V			V	
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module					V																																																			
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module					V																																															V				
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES													V																																											
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES													V																																											
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES													V																																											
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES													V																																											
2	2013	Sierra	Chassis	Electronic Suspension Control																																																								
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra	Body	Amplifier (Bose)																																																								
2	2013	Sierra	Body	Body Control Module			V																													V			V																					
2	2013	Sierra	Body	Body Control Module (aux.)																																																								
2	2013	Sierra	Body	Digital Radio Receiver																																																								
2	2013	Sierra	Body	Driver Door Switch																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2013	Sierra	Body	HVAC Control Module Auto																																																								
2	2013	Sierra	Body	HVAC Control Module Manual																																																								
2	2013	Sierra	Body	Instrument Panel Cluster																																																								
2	2013	Sierra	Body	Memory Seat Module																					V	V																																		
2	2013	Sierra	Body	Park Assist Module																																																								
2	2013	Sierra	Body	Passenger Door Switch																																																								
2	2013	Sierra	Body	Passenger Presence System																																																								
2	2013	Sierra	Body	Radio																																																								
2	2013	Sierra	Body	Navigation Radio																																																								
2	2013	Sierra	Body	Rear Heated Seat Module																																																								
2	2013	Sierra	Body	Rear HVAC/RSA																																																								
2	2013	Sierra	Body	Supplemental Inflatable Restraint																																																								
2	2013	Sierra	Body	Theft Deterrent Module		V																																																						
2	2013	Sierra Hybrid	Powertrain	Engine Control Module					V																																															V				
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																								
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																								
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																								
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																								
2	2013	Sierra Hybrid	Body	Body Control Module			V																													V			V																					
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																								
2	2013	Sierra Hybrid	Body	Driver Door Switch																																																								
2	2013	Sierra Hybrid	Body	Heated Seat Module																																																								
2	2013	Sierra Hybrid	Body	HVAC Control Module																																																								
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
2	2013	Sierra Hybrid	Body	Park Assist Module																																																								
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																																								
2	2013	Sierra Hybrid	Body	Passenger Presence System																																																								
2	2013	Sierra Hybrid	Body	Radio																																																								
2	2013	Sierra Hybrid	Body	Navigation Radio																																																								
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
2	2013	Sierra Hybrid	Body	Theft Deterrent Module		V																																																						
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																															V				
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																			
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
2	2013	Yukon	Chassis	Electronic Brake Control Module													V																																											
2	2013	Yukon	Chassis	Electronic Suspension Control																																																									
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon	Body	Amplifier (Bose)																																																									
2	2013	Yukon	Body	Assist Step Controller																																																									
2	2013	Yukon	Body	Body Control Module			V																													V			V																						
2	2013	Yukon	Body	Body Control Module (aux.)																																																									
2	2013	Yukon	Body	Digital Radio Receiver																																																									
2	2013	Yukon	Body	Driver Door Switch																																																									
2	2013	Yukon	Body	HVAC Control Module Auto																																																									
2	2013	Yukon	Body	HVAC Control Module Manual																																																									
2	2013	Yukon	Body	Instrument Panel Cluster																																																									
2	2013	Yukon	Body	Left Side Object Detection Module																																																									
2	2013	Yukon	Body	Lift Gate Module																																																									
2	2013	Yukon	Body	Memory Seat Module																					V	V																																			
2	2013	Yukon	Body	Park Assist Module																																																									
2	2013	Yukon	Body	Passenger Door Switch																																																									
2	2013	Yukon	Body	Passenger Presence System																																																									
2	2013	Yukon	Body	Radio																																																									
2	2013	Yukon	Body	Navigation Radio																																																									
2	2013	Yukon	Body	Rear Heated Seat Module																																																									
2	2013	Yukon	Body	Rear HVAC/RSA																																																									
2	2013	Yukon	Body	Right Side Object Detection Module																																																									
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																																									
2	2013	Yukon	Body	Theft Deterrent Module		V																																																							
2	2013	Yukon Hybrid	Powertrain	Engine Control Module					V																																																V			
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																									
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																									
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																									
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																									
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																									
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																									
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																									
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																									
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																									
2	2013	Yukon Hybrid	Body	Body Control Module			V																													V			V																						
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																									
2	2013	Yukon Hybrid	Body	Driver Door Switch																																																									
2	2013	Yukon Hybrid	Body	Heated Seat Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2013	Yukon Hybrid	Body	HVAC Control Module																																																									
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																									
2	2013	Yukon Hybrid	Body	Lift Gate Module																																																									
2	2013	Yukon Hybrid	Body	Park Assist Module																																																									
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																																									
2	2013	Yukon Hybrid	Body	Passenger Presence System																																																									
2	2013	Yukon Hybrid	Body	Radio																																																									
2	2013	Yukon Hybrid	Body	Navigation Radio																																																									
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
2	2013	Yukon Hybrid	Body	Theft Deterrent Module		V																																																							
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module					V																																																			V		
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																									
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																									
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module					V																																																			V		
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																									
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																									
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																			V		
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																									
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module					V																																																			V		
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW													V																																												
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW													V																																												
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																									
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon XL	Body	Amplifier (Bose)																																																									
2	2013	Yukon XL	Body	Assist Step Controller																																																									
2	2013	Yukon XL	Body	Body Control Module			V																													V			V																						
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																									
2	2013	Yukon XL	Body	Digital Radio Receiver																																																									
2	2013	Yukon XL	Body	Driver Door Switch																																																									
2	2013	Yukon XL	Body	HVAC Control Module Auto																																																									
2	2013	Yukon XL	Body	HVAC Control Module Manual																																																									
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																									
2	2013	Yukon XL	Body	Left Side Object Detection Module																																																									
2	2013	Yukon XL	Body	Lift Gate Module																																																									
2	2013	Yukon XL	Body	Memory Seat Module																					V	V																																			
2	2013	Yukon XL	Body	Park Assist Module																																																									
2	2013	Yukon XL	Body	Passenger Door Switch																																																									
2	2013	Yukon XL	Body	Passenger Presence System																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2013	Yukon XL	Body	Radio																																																									
2	2013	Yukon XL	Body	Navigation Radio																																																									
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																									
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																									
2	2013	Yukon XL	Body	Right Side Object Detection Module																																																									
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
2	2013	Yukon XL	Body	Theft Deterrent Module		V																																																							
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																									
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2014	Sierra	Chassis	Electronic Brake Control Module																																																									
2	2014	Sierra	Chassis	Parking Brake Control Module																																																									
2	2014	Sierra	Chassis	Power Steering Control Module																																																									
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2014	Sierra	Body	Body Control Module																																																									
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2014	Sierra	Body	Passenger Presence Module																																																									
2	2014	Sierra	Body	Instrument Cluster																																																									
2	2014	Sierra	Body	Radio Control																																																									
2	2014	Sierra	Body	HVAC Control																																																									
2	2014	Sierra	Body	Radio																																																									
2	2014	Sierra	Body	Amplifier																																																									
2	2014	Sierra	Body	Media Disc Player																																																									
2	2014	Sierra	Body	Human Machine Interface Control Module																																																									
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																									
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																									
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																									
2	2014	Sierra	Body	Parking Assist Control Module																																																									
2	2014	Sierra	Body	Frontview Camera Module																																																									
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																									
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																									
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																									
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																									
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2014	Sierra HD	Chassis	Suspension Control Module																																																											
2	2014	Sierra HD	Body	Body Control Module																																																												
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2014	Sierra HD	Body	Instrument Cluster																																																												
2	2014	Sierra HD	Body	Base Radio																																																												
2	2014	Sierra HD	Body	Navigation Radio																																																												
2	2014	Sierra HD	Body	Uplevel Radio																																																												
2	2014	Sierra HD	Body	Amplifier																																																												
2	2014	Sierra HD	Body	Rear Audio Control Module																																																												
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																												
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																												
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																												
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																												
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																												
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																												
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																												
2	2014	Sierra HD	Body	Seat Memory Control Module																																																												
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																												
2	2014	Sierra HD	Body	Parking Assist Control Module																																																												
2	2014	Sierra HD	Body	Theft Deterrent Module		V																																																										
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																												
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																												
2	2014	Yukon	Chassis	Parking Brake Control Module																																																												
2	2014	Yukon	Chassis	Suspension Control Module																																																												
2	2014	Yukon	Body	Body Control Module																																																												
2	2014	Yukon	Body	Auxiliary Body Control Module																																																												
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2014	Yukon	Body	Passenger Presence Module																																																												
2	2014	Yukon	Body	Instrument Cluster																																																												
2	2014	Yukon	Body	Base Radio																																																												
2	2014	Yukon	Body	Navigation Radio																																																												
2	2014	Yukon	Body	Uplevel Radio																																																												
2	2014	Yukon	Body	Amplifier																																																												
2	2014	Yukon	Body	Rear Audio Control Module																																																												
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																												
2	2014	Yukon	Body	Personal Audio Link Control Module																																																												
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																												
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																												

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Yukon	Body	Liftgate Control Module																																																											
2	2014	Yukon	Body	Seat Memory Control Module																																																											
2	2014	Yukon	Body	Rear Seat Heating Control Module																																																											
2	2014	Yukon	Body	Assist Step Control Module																																																											
2	2014	Yukon	Body	Right Side Object Detection Control Module																																																											
2	2014	Yukon	Body	Left Side Object Detection Control Module																																																											
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																											
2	2014	Yukon	Body	Parking Assist Control Module																																																											
2	2014	Yukon	Body	Theft Deterrent Module		V																																																									
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																											
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																											
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																											
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																											
2	2014	Yukon XL	Chassis	Suspension Control Module																																																											
2	2014	Yukon XL	Body	Body Control Module																																																											
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																											
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2014	Yukon XL	Body	Passenger Presence Module																																																											
2	2014	Yukon XL	Body	Instrument Cluster																																																											
2	2014	Yukon XL	Body	Base Radio																																																											
2	2014	Yukon XL	Body	Navigation Radio																																																											
2	2014	Yukon XL	Body	Uplevel Radio																																																											
2	2014	Yukon XL	Body	Amplifier																																																											
2	2014	Yukon XL	Body	Rear Audio Control Module																																																											
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																											
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																											
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																											
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																											
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																											
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																											
2	2014	Yukon XL	Body	Liftgate Control Module																																																											
2	2014	Yukon XL	Body	Seat Memory Control Module																																																											
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																											
2	2014	Yukon XL	Body	Assist Step Control Module																																																											
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																											
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																											
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																											
2	2014	Yukon XL	Body	Parking Assist Control Module																																																											
2	2014	Yukon XL	Body	Theft Deterrent Module		V																																																									
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Sierra	Chassis	Electronic Brake Control Module																																																										
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Sierra	Chassis	Power Steering Control Module																																																										
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Sierra	Chassis	Suspension Control Module																																																										
2	2015	Sierra	Body	Body Control Module																																																										
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Sierra	Body	Passenger Presence Module																																																										
2	2015	Sierra	Body	Instrument Cluster																																																										
2	2015	Sierra	Body	Radio Controls																																																										
2	2015	Sierra	Body	HVAC Controls																																																										
2	2015	Sierra	Body	Radio																																																										
2	2015	Sierra	Body	Amplifier																																																										
2	2015	Sierra	Body	Media Disc Player																																																										
2	2015	Sierra	Body	Human Machine Interface Control Module																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2015	Sierra	Body	Parking Assist Control Module																																																										
2	2015	Sierra	Body	Frontview Camera Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																										
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																										
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																										
2	2015	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Yukon	Chassis	Parking Brake Control Module																																																										
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																										
2	2015	Yukon	Chassis	Power Steering Control Module																																																										
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Yukon	Chassis	Suspension Control Module																																																										
2	2015	Yukon	Body	Body Control Module																																																										
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Yukon	Body	Passenger Presence Module																																																										
2	2015	Yukon	Body	Instrument Cluster																																																										
2	2015	Yukon	Body	Radio Controls																																																										
2	2015	Yukon	Body	HVAC Controls																																																										
2	2015	Yukon	Body	Radio																																																										
2	2015	Yukon	Body	Amplifier																																																										
2	2015	Yukon	Body	Media Disc Player																																																										
2	2015	Yukon	Body	Human Machine Interface Control Module																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Yukon	Body	HVAC Control Module																																																										
2	2015	Yukon	Body	Liftgate Control Module																																																										
2	2015	Yukon	Body	Keyless Entry Control Module																																																										
2	2015	Yukon	Body	Assist Step Control Module																																																										
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																										
2	2015	Yukon	Body	Parking Assist Control Module																																																										
2	2015	Yukon	Body	Frontview Camera Module																																																										
2	2015	Yukon	Body	Steering Column Lock Control Module																																																										
2	2015	Yukon	Body	Battery Energy Control Module																																																										
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
2	2015	Yukon XL	Chassis	Power Steering Control Module																																																										
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Yukon XL	Chassis	Suspension Control Module																																																										
2	2015	Yukon XL	Body	Body Control Module																																																										
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Yukon XL	Body	Passenger Presence Module																																																										
2	2015	Yukon XL	Body	Instrument Cluster																																																										
2	2015	Yukon XL	Body	Radio Controls																																																										
2	2015	Yukon XL	Body	HVAC Controls																																																										
2	2015	Yukon XL	Body	Radio																																																										
2	2015	Yukon XL	Body	Amplifier																																																										
2	2015	Yukon XL	Body	Media Disc Player																																																										
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Yukon XL	Body	HVAC Control Module																																																										
2	2015	Yukon XL	Body	Liftgate Control Module																																																										
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
2	2015	Yukon XL	Body	Assist Step Control Module																																																										
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
2	2015	Yukon XL	Body	Parking Assist Control Module																																																										
2	2015	Yukon XL	Body	Frontview Camera Module																																																										
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2016	Sierra	Chassis	Electronic Brake Control Module																																																									
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																									
2	2016	Sierra	Chassis	Parking Brake Control Module																																																									
2	2016	Sierra	Chassis	Power Steering Control Module																																																									
2	2016	Sierra	Chassis	Power Steering Control Module																																																									
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2016	Sierra	Chassis	Suspension Control Module																																																									
2	2016	Sierra	Body	Body Control Module																																																									
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2016	Sierra	Body	Passenger Presence Module																																																									
2	2016	Sierra	Body	Instrument Cluster																																																									
2	2016	Sierra	Body	Radio Controls																																																									
2	2016	Sierra	Body	HVAC Controls																																																									
2	2016	Sierra	Body	Radio (IO3)																																																									
2	2016	Sierra	Body	Radio (IOB)																																																									
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																									
2	2016	Sierra	Body	Amplifier																																																									
2	2016	Sierra	Body	Media Disc Player																																																									
2	2016	Sierra	Body	Human Machine Interface Control Module																																																									
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																									
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																									
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																									
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																									
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																									
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																									
2	2016	Sierra	Body	Parking Assist Control Module																																																									
2	2016	Sierra	Body	Frontview Camera Module																																																									
2	2016	Sierra	Body	Frontview Camera Module																																																									
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2016	Yukon	Chassis	Electronic Brake Control Module																																																									
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																									
2	2016	Yukon	Chassis	Parking Brake Control Module																																																									
2	2016	Yukon	Chassis	Power Steering Control Module																																																									
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2016	Yukon	Chassis	Suspension Control Module																																																									
2	2016	Yukon	Body	Body Control Module																																																									
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2016	Yukon	Body	Passenger Presence Module																																																									
2	2016	Yukon	Body	Instrument Cluster																																																									
2	2016	Yukon	Body	Radio Controls																																																									
2	2016	Yukon	Body	HVAC Controls																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
2	2016	Yukon	Body	Radio																																																											
2	2016	Yukon	Body	Amplifier																																																											
2	2016	Yukon	Body	Media Disc Player																																																											
2	2016	Yukon	Body	Human Machine Interface Control Module																																																											
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																											
2	2016	Yukon	Body	HVAC Control Module																																																											
2	2016	Yukon	Body	Liftgate Control Module																																																											
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																											
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																											
2	2016	Yukon	Body	Keyless Entry Control Module																																																											
2	2016	Yukon	Body	Assist Step Control Module																																																											
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																											
2	2016	Yukon	Body	Parking Assist Control Module																																																											
2	2016	Yukon	Body	Frontview Camera Module																																																											
2	2016	Yukon	Body	Steering Column Lock Control Module																																																											
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																											
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																											
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																											
2	2016	Yukon XL	Chassis	Power Steering Control Module																																																											
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2016	Yukon XL	Chassis	Suspension Control Module																																																											
2	2016	Yukon XL	Body	Body Control Module																																																											
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2016	Yukon XL	Body	Passenger Presence Module																																																											
2	2016	Yukon XL	Body	Instrument Cluster																																																											
2	2016	Yukon XL	Body	Radio Controls																																																											
2	2016	Yukon XL	Body	HVAC Controls																																																											
2	2016	Yukon XL	Body	Radio																																																											
2	2016	Yukon XL	Body	Amplifier																																																											
2	2016	Yukon XL	Body	Media Disc Player																																																											
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																											
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																											
2	2016	Yukon XL	Body	HVAC Control Module																																																											
2	2016	Yukon XL	Body	Liftgate Control Module																																																											
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																											
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																											
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																											
2	2016	Yukon XL	Body	Assist Step Control Module																																																											
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																											
2	2016	Yukon XL	Body	Parking Assist Control Module																																																											
2	2016	Yukon XL	Body	Frontview Camera Module																																																											
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																											
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																																			V		V
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																			V
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module					V																																															V			V
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
5	2011	ALL	Chassis	Electronic Brake Control Module											V	V																																												
5	2011	ALL	Body	Body Control Module																																								V		V														
5	2011	ALL	Body	Digital Radio Receiver																																																								
5	2011	ALL	Body	Generator Battery Control Module																																																								
5	2011	ALL	Body	Instrument Panel Cluster																																																								
5	2011	ALL	Body	Passenger Presence System																																																								
5	2011	ALL	Body	Personal Audio Link Module																																																								
5	2011	ALL	Body	Base Radio																																																								
5	2011	ALL	Body	Uplevel Radio																																																								
5	2011	ALL	Body	Supplemental Inflatable Restraint	V																																																								
5	2011	ALL	Body	Theft Deterrent Module		V																																																							
5	2011	ALL	Body	Vehicle Comm. Interface Module																																															V			V						
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																															V			V
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																			V
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module					V																																															V			V
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
5	2012	ALL	Chassis	Electronic Brake Control Module											V	V																																												
5	2012	ALL	Body	Body Control Module																																								V		V														
5	2012	ALL	Body	Digital Radio Receiver																																																								
5	2012	ALL	Body	Generator Battery Control Module																																																								
5	2012	ALL	Body	Instrument Panel Cluster																																																								
5	2012	ALL	Body	Passenger Presence System																																																								
5	2012	ALL	Body	Personal Audio Link Module																																																								
5	2012	ALL	Body	Base Radio																																																								
5	2012	ALL	Body	Uplevel Radio																																																								
5	2012	ALL	Body	Supplemental Inflatable Restraint	V																																																								
5	2012	ALL	Body	Theft Deterrent Module		V																																																							
5	2012	ALL	Body	Vehicle Comm. Interface Module																																															V			V						
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
5	2015	Canyon	Powertrain	Chassis Control Module																																																								
5	2015	Canyon	Powertrain	Transfer Case Control Module																																																								
5	2015	Canyon	Chassis	Electronic Brake Control Module																																																								
5	2015	Canyon	Chassis	Power Steering Control Module																																																								
5	2015	Canyon	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
5	2015	Canyon	Body	Passenger Presence Module																																																										
5	2015	Canyon	Body	Radio																																																										
5	2015	Canyon	Body	Amplifier																																																										
5	2015	Canyon	Body	Human Machine Interface Control Module																																																										
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																																										
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
5	2015	Canyon	Body	Parking Assist Control Module																																																										
5	2015	Canyon	Body	Frontview Camera Module																																																										
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
5	2016	Canyon	Powertrain	Transfer Case Control Module																																																										
5	2016	Canyon	Chassis	Electronic Brake Control Module																																																										
5	2016	Canyon	Chassis	Power Steering Control Module																																																										
5	2016	Canyon	Body	Body Control Module																																																										
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
5	2016	Canyon	Body	Passenger Presence Module																																																										
5	2016	Canyon	Body	Trailer Interface Control Module																																																										
5	2016	Canyon	Body	Radio																																																										
5	2016	Canyon	Body	Amplifier																																																										
5	2016	Canyon	Body	Human Machine Interface Control Module																																																										
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																																										
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
5	2016	Canyon	Body	Frontview Camera Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																																	V		V
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																					V
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module					V																																																	V		V
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
6	2011	ALL	Chassis	Electronic Brake Control Module										V	V																																															
6	2011	ALL	Body	Body Control Module																																								V		V																
6	2011	ALL	Body	Digital Radio Receiver																																																										
6	2011	ALL	Body	Generator Battery Control Module																																																										
6	2011	ALL	Body	Instrument Panel Cluster																																																										
6	2011	ALL	Body	Passenger Presence System																																																										
6	2011	ALL	Body	Personal Audio Link Module																																																										
6	2011	ALL	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
6	2011	ALL	Body	Uplevel Radio																																																										
6	2011	ALL	Body	Supplemental Inflatable Restraint	V																																																									
6	2011	ALL	Body	Theft Deterrent Module		V																																																								
6	2011	ALL	Body	Vehicle Comm. Interface Module																																															V		V									
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module					V																																															V		V
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module					V																																																				V	
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module					V																																															V					V	
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
6	2012	ALL	Chassis	Electronic Brake Control Module										V	V																																															
6	2012	ALL	Body	Body Control Module																																									V		V															
6	2012	ALL	Body	Digital Radio Receiver																																																										
6	2012	ALL	Body	Generator Battery Control Module																																																										
6	2012	ALL	Body	Instrument Panel Cluster																																																										
6	2012	ALL	Body	Passenger Presence System																																																										
6	2012	ALL	Body	Personal Audio Link Module																																																										
6	2012	ALL	Body	Base Radio																																																										
6	2012	ALL	Body	Uplevel Radio																																																										
6	2012	ALL	Body	Supplemental Inflatable Restraint	V																																																									
6	2012	ALL	Body	Theft Deterrent Module		V																																																								
6	2012	ALL	Body	Vehicle Comm. Interface Module																																															V		V									
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
6	2015	Canyon	Powertrain	Chassis Control Module																																																										
6	2015	Canyon	Powertrain	Transfer Case Control Module																																																										
6	2015	Canyon	Chassis	Electronic Brake Control Module																																																										
6	2015	Canyon	Chassis	Power Steering Control Module																																																										
6	2015	Canyon	Body	Body Control Module																																																										
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
6	2015	Canyon	Body	Passenger Presence Module																																																										
6	2015	Canyon	Body	Radio																																																										
6	2015	Canyon	Body	Amplifier																																																										
6	2015	Canyon	Body	Human Machine Interface Control Module																																																										
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																																										
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
6	2015	Canyon	Body	Parking Assist Control Module																																																										
6	2015	Canyon	Body	Frontview Camera Module																																																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																									
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																									
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
6	2016	Canyon	Powertrain	Transfer Case Control Module																																																									
6	2016	Canyon	Chassis	Electronic Brake Control Module																																																									
6	2016	Canyon	Chassis	Power Steering Control Module																																																									
6	2016	Canyon	Body	Body Control Module																																																									
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
6	2016	Canyon	Body	Passenger Presence Module																																																									
6	2016	Canyon	Body	Trailer Interface Control Module																																																									
6	2016	Canyon	Body	Radio																																																									
6	2016	Canyon	Body	Amplifier																																																									
6	2016	Canyon	Body	Human Machine Interface Control Module																																																									
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																																									
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																									
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																									
6	2016	Canyon	Body	Frontview Camera Module																																																									
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V			V
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V				
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V				
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V				
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																															V				V
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																															V				
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																											
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																											
7	2011	Express/Savana	Body	Body Control Module			V																																																						
7	2011	Express/Savana	Body	Digital Radio Receiver																																																									
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																									
7	2011	Express/Savana	Body	Passenger Presence System																																																									
7	2011	Express/Savana	Body	Radio																																																								
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
7	2011	Express/Savana	Body	Rollover Sensor																																																									
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																					
7	2011	Express/Savana	Body	Theft Deterrent Module		V																																																							
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																															V				V
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																															V				
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V				
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																														V			
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																						
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																														V			V
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																						
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																													V			
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																						
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																									
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																									
7	2011	Express Access/Savana Pro	Body	Body Control Module			V																																																					
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																							
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																						
7	2011	Express Access/Savana Pro	Body	Radio																																																						
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																						
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																			
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																					
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																														V			V
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																														V			
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																						
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																														V			
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																						
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																														V			
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																						
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																														V			V
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																						
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																														V			
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																						
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																									
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																									
7	2012	Express/Savana	Body	Body Control Module			V																																V																				
7	2012	Express/Savana	Body	Digital Radio Receiver																																																						
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																						
7	2012	Express/Savana	Body	Passenger Presence System																																																						
7	2012	Express/Savana	Body	Radio																																																					
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
7	2012	Express/Savana	Body	Rollover Sensor																																																						
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																			
7	2012	Express/Savana	Body	Theft Deterrent Module		V																																																					
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																														V			V
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																														V			
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																						
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																														V			

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																V			
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																																V			V
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																																V			
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																											
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																											
7	2012	Express Access/Savana Pro	Body	Body Control Module			V																																V																					
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																								
7	2012	Express Access/Savana Pro	Body	Radio																																																								
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																					
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																						
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																																V			V
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																																V			
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																																V			
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																																V			
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																																V			V
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																																V			
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																											
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																											
7	2013	Express/Savana	Body	Body Control Module			V																																V																					
7	2013	Express/Savana	Body	Digital Radio Receiver																																																								
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
7	2013	Express/Savana	Body	Passenger Presence System																																																								
7	2013	Express/Savana	Body	Radio																																																								
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
7	2013	Express/Savana	Body	Rollover Sensor																																																								
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																					
7	2013	Express/Savana	Body	Theft Deterrent Module		V																																																						
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module					V																																																V			V
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																																V			
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V			
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																						
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V			
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																						
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																															V			V
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																						
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module					V																																															V			
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																						
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																						
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																									
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																									
7	2013	Express Access/Savana Pro	Body	Body Control Module			V																																V																				
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																						
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																						
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																						
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																						
7	2013	Express Access/Savana Pro	Body	Radio																																																						
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																						
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																				
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																					
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																						
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																						
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																						
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																						
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																						
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																						
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																						
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																						
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																						
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																						
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																						
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																						
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																						
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																						
7	2014	Savana	Chassis	Electronic Brake Control Module																																																						
7	2014	Savana	Body	Body Control Module																																																						
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																			V																																				
7	2014	Savana	Body	Passenger Presence Module																																																						
7	2014	Savana	Body	Rollover Sensor Module																																																						
7	2014	Savana	Body	Instrument Cluster																																																						
7	2014	Savana	Body	Chime Alarm Control Module																																																						
7	2014	Savana	Body	Base Radio																																																						
7	2014	Savana	Body	Navigation Radio																																																						
7	2014	Savana	Body	Uplevel Radio																																																						
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																						
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																						
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
7	2014	Savana	Body	Auxiliary Heater Control Module																																																										
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2014	Savana	Body	Parking Assist Control Module																																																										
7	2014	Savana	Body	Theft Deterrent Module		V																																																								
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2015	Savana	Chassis	Electronic Brake Control Module																																																										
7	2015	Savana	Body	Body Control Module																																																										
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																			V																																							
7	2015	Savana	Body	Rollover Sensor Module																																																										
7	2015	Savana	Body	Instrument Cluster																																																										
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
7	2015	Savana	Body	Auxiliary Heater Control Module																																																										
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2015	Savana	Body	Parking Assist Control Module																																																										
7	2015	Savana	Body	Theft Deterrent Module		V																																																								
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2016	Savana	Chassis	Electronic Brake Control Module																																																										
7	2016	Savana	Body	Body Control Module																																																										
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2016	Savana	Body	Instrument Cluster																																																										
7	2016	Savana	Body	Chime Alarm Control Module																																																										
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
7	2016	Savana	Body	Auxiliary Heater Control Module																																																										
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2016	Savana	Body	Parking Assist Control Module																																																										
7	2016	Savana	Body	Theft Deterrent Module		V																																																								
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																																V				
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																															V				
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																															V				

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																														V			V
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																										
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																										
8	2011	Express/Savana	Body	Body Control Module			V																																																					
8	2011	Express/Savana	Body	Digital Radio Receiver																																																								
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																								
8	2011	Express/Savana	Body	Passenger Presence System																																																								
8	2011	Express/Savana	Body	Radio																																																								
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
8	2011	Express/Savana	Body	Rollover Sensor																																																								
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																					
8	2011	Express/Savana	Body	Theft Deterrent Module		V																																																						
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																														V				
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																													V				
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																													V				
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																													V			V
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																										
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																										
8	2011	Express Access/Savana Pro	Body	Body Control Module			V																																																					
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																								
8	2011	Express Access/Savana Pro	Body	Radio																																																								
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																								
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																					
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																						
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																														V				
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																													V				
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																													V				
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																													V			V
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																										
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																										
8	2012	Express/Savana	Body	Body Control Module			V																																V																				
8	2012	Express/Savana	Body	Digital Radio Receiver																																																								
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																								
8	2012	Express/Savana	Body	Passenger Presence System																																																								
8	2012	Express/Savana	Body	Radio																																																								
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																								

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
8	2012	Express/Savana	Body	Rollover Sensor																																																								
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																					
8	2012	Express/Savana	Body	Theft Deterrent Module		V																																																						
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																														V			
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																														V			
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																														V			
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																														V			V
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																											
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																											
8	2012	Express Access/Savana Pro	Body	Body Control Module			V																																V																					
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																								
8	2012	Express Access/Savana Pro	Body	Radio																																																								
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																					
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																						
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																														V			
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																														V			
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																														V			
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																														V			V
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES													V																																											
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES													V																																											
8	2013	Express/Savana	Body	Body Control Module			V																																V																					
8	2013	Express/Savana	Body	Digital Radio Receiver																																																								
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
8	2013	Express/Savana	Body	Navigation Radio																																																								
8	2013	Express/Savana	Body	Park Assist Module																																																								
8	2013	Express/Savana	Body	Passenger Presence System																																																								
8	2013	Express/Savana	Body	Radio																																																								
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
8	2013	Express/Savana	Body	Rollover Sensor																																																								
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																			V																																					
8	2013	Express/Savana	Body	Theft Deterrent Module		V																																																						
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module					V																																														V			
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module					V																																														V			
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module					V																																														V			

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module					V																																														V			V
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																							
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES													V																																										
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES													V																																										
8	2013	Express Access/Savana Pro	Body	Body Control Module			V																																V																					
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																							
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																							
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																																							
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																							
8	2013	Express Access/Savana Pro	Body	Radio																																																							
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																							
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																			V																																				
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module		V																																																					
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																							
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																							
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																							
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																							
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																							
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																							
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																							
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																							
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																							
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																							
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																							
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																							
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																							
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																							
8	2014	Savana	Chassis	Electronic Brake Control Module																																																							
8	2014	Savana	Body	Body Control Module																																																							
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																			V																																				
8	2014	Savana	Body	Passenger Presence Module																																																							
8	2014	Savana	Body	Rollover Sensor Module																																																							
8	2014	Savana	Body	Instrument Cluster																																																							
8	2014	Savana	Body	Chime Alarm Control Module																																																							
8	2014	Savana	Body	Base Radio																																																							
8	2014	Savana	Body	Navigation Radio																																																							
8	2014	Savana	Body	Uplevel Radio																																																							
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																							
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																							
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																							
8	2014	Savana	Body	Auxiliary Heater Control Module																																																							
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																							
8	2014	Savana	Body	Parking Assist Control Module																																																							
8	2014	Savana	Body	Theft Deterrent Module		V																																																					
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																							
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																							
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																							
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
8	2015	Savana	Chassis	Electronic Brake Control Module																																																										
8	2015	Savana	Body	Body Control Module																																																										
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																			V																																							
8	2015	Savana	Body	Rollover Sensor Module																																																										
8	2015	Savana	Body	Instrument Cluster																																																										
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
8	2015	Savana	Body	Auxiliary Heater Control Module																																																										
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
8	2015	Savana	Body	Parking Assist Control Module																																																										
8	2015	Savana	Body	Theft Deterrent Module		V																																																								
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
8	2016	Savana	Chassis	Electronic Brake Control Module																																																										
8	2016	Savana	Body	Body Control Module																																																										
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
8	2016	Savana	Body	Instrument Cluster																																																										
8	2016	Savana	Body	Chime Alarm Control Module																																																										
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
8	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
8	2016	Savana	Body	Auxiliary Heater Control Module																																																										
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
8	2016	Savana	Body	Parking Assist Control Module																																																										
8	2016	Savana	Body	Theft Deterrent Module		V																																																								
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module			V	V	V																																																					
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																										
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																										
ALL	2004	ALL	Chassis	ABS																																																										
ALL	2004	ALL	Chassis	Air Suspension																																																										
ALL	2004	ALL	Body	Amplifier (Bose)																																																										
ALL	2004	ALL	Body	Body Control Module																													V																													
ALL	2004	ALL	Body	Digital Radio Receiver																																																										
ALL	2004	ALL	Body	Driver Door Module																																																										
ALL	2004	ALL	Body	Driver Seat Module																			V																																							
ALL	2004	ALL	Body	Heating and Air Conditioning																			V																																							
ALL	2004	ALL	Body	Instrument Panel Cluster																																																										
ALL	2004	ALL	Body	OnStar																																																										
ALL	2004	ALL	Body	Passenger Door Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
ALL	2004	ALL	Body	Uplevel Radio																																																									
ALL	2004	ALL	Body	Navigation Radio								V																																																
ALL	2004	ALL	Body	Rear Seat Audio																																																									
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module			V	V	V																																																				
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																										
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																										
ALL	2005	ALL	Chassis	ABS																																																										
ALL	2005	ALL	Chassis	Air Suspension																																																										
ALL	2005	ALL	Body	Body Control Module																													V																														
ALL	2005	ALL	Body	Digital Radio Receiver																																																										
ALL	2005	ALL	Body	Driver Door Module (SUV)																																																										
ALL	2005	ALL	Body	Driver Door Module (SUT)																																																										
ALL	2005	ALL	Body	Driver Seat Module																			V																																							
ALL	2005	ALL	Body	Heating and Air Conditioning																			V																																							
ALL	2005	ALL	Body	Instrument Panel Cluster																																																										
ALL	2005	ALL	Body	Passenger Door Module																																																										
ALL	2005	ALL	Body	Uplevel Radio																																																										
ALL	2005	ALL	Body	Navigation Radio								V																																																	
ALL	2005	ALL	Body	Rear Seat Audio																																																										
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module			V	V	V																																																				
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																										
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																										
ALL	2006	H2	Chassis	ABS																																																										
ALL	2006	H2	Chassis	Air Suspension																																																										
ALL	2006	H2	Body	Body Control Module																													V																														
ALL	2006	H2	Body	Digital Radio Receiver																																																										
ALL	2006	H2	Body	Driver Door Module (SUV)																																																										
ALL	2006	H2	Body	Driver Door Module (SUT)																																																										
ALL	2006	H2	Body	Driver Seat Module																			V																																							
ALL	2006	H2	Body	Heating and Air Conditioning																			V																																							
ALL	2006	H2	Body	Instrument Panel Cluster																																																										
ALL	2006	H2	Body	Passenger Door Module																																																										
ALL	2006	H2	Body	Uplevel Radio																																																										
ALL	2006	H2	Body	Navigation Radio								V																																																	
ALL	2006	H2	Body	Rear Seat Audio																																																										
ALL	2006	H2	Body	Supplemental Inflatable Restraint	V																																																									
ALL	2006	H3	Powertrain	Engine Control Module			V		V																																																					
ALL	2006	H3	Powertrain	Transmission Control Module																																																										
ALL	2006	H3	Powertrain	Transfer Case Control Module																																																										
ALL	2006	H3	Chassis	Antilock Brake System										V																																															
ALL	2006	H3	Body	Body Control Module																																								V		V															
ALL	2006	H3	Body	Digital Radio Receiver																																																										
ALL	2006	H3	Body	Instrument Panel Cluster																																																										
ALL	2006	H3	Body	Uplevel Radio																																																										
ALL	2006	H3	Body	Navigation Radio								V																																																	
ALL	2006	H3	Body	Supplemental Inflatable Restraint	V																																																									
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module			V	V	V																																																					
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																										
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
ALL	2007	H2	Chassis	ABS																																																									
ALL	2007	H2	Chassis	Air Suspension																																																									
ALL	2007	H2	Body	Amplifier (Bose)																																																									
ALL	2007	H2	Body	Body Control Module																												V																													
ALL	2007	H2	Body	Digital Radio Receiver																																																									
ALL	2007	H2	Body	Driver Door Module (SUV)																																																									
ALL	2007	H2	Body	Driver Door Module (SUT)																																																									
ALL	2007	H2	Body	Driver Seat Module																			V																																							
ALL	2007	H2	Body	HVAC Control Module																			V																																							
ALL	2007	H2	Body	Instrument Panel Cluster																																																									
ALL	2007	H2	Body	Passenger Door Module																																											V															
ALL	2007	H2	Body	Uplevel Radio																																																									
ALL	2007	H2	Body	Navigation Radio								V																																																	
ALL	2007	H2	Body	Rear Seat Audio																																																									
ALL	2007	H2	Body	Supplemental Inflatable Restraint	V																																																								
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																																V	V	V						
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module			V		V																																																				
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																									
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																									
ALL	2007	H3	Chassis	EBCM											V																																														
ALL	2007	H3	Body	Body Control Module (5GT)																																									V		V														
ALL	2007	H3	Body	Body Control Module (ADM)																																									V		V														
ALL	2007	H3	Body	Digital Radio Receiver																																																									
ALL	2007	H3	Body	Generator Battery Control Module																																																									
ALL	2007	H3	Body	Instrument Panel Cluster																																																									
ALL	2007	H3	Body	Personal Audio Link Module																																																									
ALL	2007	H3	Body	Uplevel Radio																																																									
ALL	2007	H3	Body	Navigation Radio								V																																																	
ALL	2007	H3	Body	Supplemental Inflatable Restraint	V																																																								
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																															V	V	V						
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module			V		V																																																				
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																									
ALL	2008	H2	Chassis	Air SCM																																																									
ALL	2008	H2	Chassis	EBCM																																																									
ALL	2008	H2	Body	Amplifier (Bose)																																																									
ALL	2008	H2	Body	Body Control Module			V																													V																										
ALL	2008	H2	Body	Digital Radio Receiver																																																									
ALL	2008	H2	Body	Driver Door Switch																																																									
ALL	2008	H2	Body	HVAC Control Module																																																									
ALL	2008	H2	Body	Instrument Panel Cluster																																																									
ALL	2008	H2	Body	Memory Seat Module																					V	V																																				
ALL	2008	H2	Body	Passenger Door Switch																																																									
ALL	2008	H2	Body	Radio																																																									
ALL	2008	H2	Body	Rear Heated Seat Module																																																									
ALL	2008	H2	Body	Rear HVAC/RSA																																																									
ALL	2008	H2	Body	Rollover Sensor																																																									
ALL	2008	H2	Body	Supplemental Inflatable Restraint																			V																																							
ALL	2008	H2	Body	Theft Deterrent Module		V																																																								
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																															V		V						

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)					V																																																	V	V	V
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)					V																																																V	V	V
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																							
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																							
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module					V																																															V		V
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																							
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																																							
ALL	2008	H3	Chassis	EBCM											V																																												
ALL	2008	H3	Body	Body Control Module (5GT)																																									V		V													
ALL	2008	H3	Body	Body Control Module (ADM)																																									V		V													
ALL	2008	H3	Body	Digital Radio Receiver																																																							
ALL	2008	H3	Body	Generator Battery Control Module																																																							
ALL	2008	H3	Body	Instrument Panel Cluster																																																							
ALL	2008	H3	Body	Personal Audio Link Module																																																							
ALL	2008	H3	Body	Uplevel Radio																																																							
ALL	2008	H3	Body	Navigation Radio								V																																															
ALL	2008	H3	Body	Supplemental Inflatable Restraint	V																																																							
ALL	2008	H3	Body	Theft Deterrent Module		V																																																						
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																																V	V	V					
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module			V		V																																																			
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																								
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																								
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																								
ALL	2009	H2	Chassis	Air SCM																																																								
ALL	2009	H2	Chassis	EBCM																																																								
ALL	2009	H2	Body	Amplifier (Bose)																																																								
ALL	2009	H2	Body	Body Control Module			V																													V																								
ALL	2009	H2	Body	Digital Radio Receiver																																																								
ALL	2009	H2	Body	Driver Door Switch																																																								
ALL	2009	H2	Body	HVAC Control Module																																																								
ALL	2009	H2	Body	Instrument Panel Cluster																																																								
ALL	2009	H2	Body	Memory Seat Module																					V	V																																		
ALL	2009	H2	Body	Passenger Door Switch																																																								
ALL	2009	H2	Body	Radio																																																								
ALL	2009	H2	Body	Rear Heated Seat Module																																																								
ALL	2009	H2	Body	Rear HVAC/RSA																																																								
ALL	2009	H2	Body	Rollover Sensor																																																								
ALL	2009	H2	Body	Supplemental Inflatable Restraint																			V																																					
ALL	2009	H2	Body	Theft Deterrent Module		V																																																						
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																															V		V						
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																															V		V						
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)					V				V																																											V	V	V
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)					V																																															V	V	V
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																							
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																							
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																							
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																							
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)					V																																														V		V
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)					V																																														V			
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																							
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																							

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2009	H3	Chassis	EBCM											V																																															
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																									V		V															
ALL	2009	H3	Body	Body Control Module (ADM)																																									V		V															
ALL	2009	H3	Body	Digital Radio Receiver																																																										
ALL	2009	H3	Body	Generator Battery Control Module																																																										
ALL	2009	H3	Body	Instrument Panel Cluster																																																										
ALL	2009	H3	Body	Personal Audio Link Module																																																										
ALL	2009	H3	Body	Uplevel Radio																																																										
ALL	2009	H3	Body	Navigation Radio								V																																																		
ALL	2009	H3	Body	Supplemental Inflatable Restraint	V																																																									
ALL	2009	H3	Body	Theft Deterrent Module		V																																																								
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																															V			V								
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module					V																																																V					
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2010	H2	Chassis	Air SCM																																																										
ALL	2010	H2	Chassis	EBCM																																																										
ALL	2010	H2	Body	Amplifier (Bose)																																																										
ALL	2010	H2	Body	Body Control Module			V																			V																																				
ALL	2010	H2	Body	Digital Radio Receiver																																																										
ALL	2010	H2	Body	Driver Door Switch																																																										
ALL	2010	H2	Body	HVAC Control Module																																																										
ALL	2010	H2	Body	Instrument Panel Cluster																																																										
ALL	2010	H2	Body	Memory Seat Module																					V	V																																				
ALL	2010	H2	Body	Passenger Door Switch																																																										
ALL	2010	H2	Body	Personal Audio Link Module																																																										
ALL	2010	H2	Body	Radio																																																										
ALL	2010	H2	Body	Rear Heated Seat Module																																																										
ALL	2010	H2	Body	Rear HVAC/RSA																																																										
ALL	2010	H2	Body	Rollover Sensor																																																										
ALL	2010	H2	Body	Supplemental Inflatable Restraint																			V																																							
ALL	2010	H2	Body	Theft Deterrent Module		V																																																								
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																															V		V									
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module					V				V																																													V	V	V		
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module					V																																																	V			V	
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2010	H3	Chassis	EBCM											V																																															
ALL	2010	H3	Body	Body Control Module																																									V		V															
ALL	2010	H3	Body	Digital Radio Receiver																																																										
ALL	2010	H3	Body	Generator Battery Control Module																																																										
ALL	2010	H3	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Setup New SDM	Learn Key Data	Cruise Control Data	Enhanced EVAP Data	Oil Life Reset	Reset Idle Learn	Radio Information	VIN Relearn	Intake CMP Actuator	Exhaust CMP Actuator	ABS Data	TCS Data	Automated Bleed	DSCC Data	Cruise Disengagement	Factory Reset	VIN Information	Disable DTC(s)	Sensor Data	Memory Data Default	Memory Data 1	Memory Data 2	Lumbar Up/Down Sensor	Lumbar Forward/Rearward Sensor	Telescope Sensor	Tilt Sensor	Column Softstops	HVAC System Data 2	Power Down Now	Exterior Lamps	Interior Lamps	Load Management	Remote Start	BPP System Data	Column Lock Relay Enable	BPP Sensor Calibration	Program VIN	Ship Mode	Bluetooth	Theft Information	Alarm Trigger	Key Fob Information	Antenna Data	Tire Pressure Data	Substitution Detection	Miscellaneous Inputs	Driver 1	Driver 2	Signal Strength	Transceiver ID	B1000 Data	ECU Information Status	Cruise/PTO/Traction Data	Manual Transmission Data	Idle Learn Reset	Auto. Transmission Data
ALL	2010	H3	Body	Personal Audio Link Module																																																									
ALL	2010	H3	Body	Uplevel Radio																																																									
ALL	2010	H3	Body	Navigation Radio								V																																																
ALL	2010	H3	Body	Supplemental Inflatable Restraint	V																																																								
ALL	2010	H3	Body	Theft Deterrent Module		V																																																							
ALL	2010	H3	Body	Vehicle Comm. Interface Module																																																V			V					

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																									
C	2004	ALL	Body	CD Changer																																																									
C	2004	ALL	Body	Chime																																																									
C	2004	ALL	Body	Driver Door Module																																																									
C	2004	ALL	Body	Driver Seat Module																																																									
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2004	ALL	Body	Instrument Panel Cluster																																																										
C	2004	ALL	Body	OnStar																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Radio Base																																																										
C	2004	ALL	Body	Radio Uplevel																																																										
C	2004	ALL	Body	Radio Navigation																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																											
C	2004	ALL	Body	Rear HVAC																																																											
C	2004	ALL	Body	Rear Seat Audio																																																											
C	2004	ALL	Body	Rear Seat Entertainment																																																											
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
C	2004	ALL	Body	Vehicle Theft Deterrent																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																											
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																											
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																											
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
C	2005	ALL	Chassis	ESC																																																										
C	2005	ALL	Chassis	Rear Wheel Steering																																																											
C	2005	ALL	Chassis	Tire Pressure Monitor																																																											
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2005	ALL	Chassis	VSES																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2005	ALL	Body	Amplifier (Bose)																																																										
C	2005	ALL	Body	Body Control Module																																																										
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																																										
C	2005	ALL	Body	Driver Seat Module																																																										
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2005	ALL	Body	Instrument Panel Cluster																																																										
C	2005	ALL	Body	Passenger Door Module																																																										
C	2005	ALL	Body	Passenger Presence System																																																										
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio																																																										
C	2005	ALL	Body	Rear Aux. Climate Module																																																										
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2005	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module					V																																																					
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module			V																																																							
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module			V																																																							
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																											
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed			V																																																								
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																											
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
C	2006	ALL	Chassis	ESC																																																										
C	2006	ALL	Chassis	Tire Pressure Monitor																																																											
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2006	ALL	Chassis	VSES																																																										
C	2006	ALL	Body	Amplifier (Bose)																																																											
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																											
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																											
C	2006	ALL	Body	Generator Battery Control Module																																																											
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																											
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																											
C	2006	ALL	Body	Instrument Panel Cluster																																																											
C	2006	ALL	Body	Passenger Door Module																																																											
C	2006	ALL	Body	Passenger Presence System																																																											
C	2006	ALL	Body	Base Radio																																																											
C	2006	ALL	Body	Uplevel Radio																																																											
C	2006	ALL	Body	Navigation Radio																																																											
C	2006	ALL	Body	Rear Aux. Climate Module																																																											
C	2006	ALL	Body	Rear HVAC																																																											
C	2006	ALL	Body	Rear Seat Audio																																																											
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
C	2006	ALL	Body	Vehicle Theft Deterrent																																																											
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																											
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V																																																							
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module				V																																																							
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																							
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																									
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																							
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module				V																																																						
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module	V			V																																																							
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																									
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																								
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module				V																																																							
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																							
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Sierra	Chassis	Electronic Suspension Control																																																												
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2007	Sierra	Body	Amplifier (Bose)																																																												
C	2007	Sierra	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																	
C	2007	Sierra	Body	Body Control Module (aux.)																																																												
C	2007	Sierra	Body	Digital Radio Receiver																																																												
C	2007	Sierra	Body	Driver Door Switch																																																												
C	2007	Sierra	Body	HVAC Control Module Auto																												V	V																															
C	2007	Sierra	Body	HVAC Control Module Manual																													V																															
C	2007	Sierra	Body	Instrument Panel Cluster																																																												
C	2007	Sierra	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																					
C	2007	Sierra	Body	Park Assist Module																																							V	V	V																		
C	2007	Sierra	Body	Passenger Door Switch																																																											
C	2007	Sierra	Body	Passenger Presence System																																										V																
C	2007	Sierra	Body	Radio																																																										
C	2007	Sierra	Body	Rear Heated Seat Module																																	V				V																					
C	2007	Sierra	Body	Rear HVAC/RSA																																																											
C	2007	Sierra	Body	Rollover Sensor																																																											
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																										V										V						
C	2007	Sierra	Body	Theft Deterrent Module																																																											
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module				V																																																								
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																								
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																								
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module				V																																																								
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																										
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Yukon	Chassis	Electronic Suspension Control																																																												
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																												
C	2007	Yukon	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2007	Yukon	Body	Assist Step Controller																																																										
C	2007	Yukon	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
C	2007	Yukon	Body	Body Control Module (aux.)																																																										
C	2007	Yukon	Body	Digital Radio Receiver																																																										
C	2007	Yukon	Body	Driver Door Switch																																																										
C	2007	Yukon	Body	HVAC Control Module Auto																											V	V																															
C	2007	Yukon	Body	HVAC Control Module Manual																												V																															
C	2007	Yukon	Body	Instrument Panel Cluster																																																										
C	2007	Yukon	Body	Lift Gate Module																																																										
C	2007	Yukon	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2007	Yukon	Body	Park Assist Module																																							V	V	V																	
C	2007	Yukon	Body	Passenger Door Switch																																																										
C	2007	Yukon	Body	Passenger Presence System																																										V																
C	2007	Yukon	Body	Radio																																																										
C	2007	Yukon	Body	Rear Heated Seat Module																																	V			V																						
C	2007	Yukon	Body	Rear HVAC/RSA																																																										
C	2007	Yukon	Body	Rollover Sensor																																																										
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																										V									V						
C	2007	Yukon	Body	Theft Deterrent Module																																																										
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module				V																																																							
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module				V																																																							
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																							
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module				V																																																							
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																									
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module				V																																																							
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																							
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2007	Yukon XL	Body	Amplifier (Bose)																																																												
C	2007	Yukon XL	Body	Assist Step Controller																																																												
C	2007	Yukon XL	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2007	Yukon XL	Body	Digital Radio Receiver																																																												
C	2007	Yukon XL	Body	Driver Door Switch																																																												
C	2007	Yukon XL	Body	HVAC Control Module Auto																											V	V																															
C	2007	Yukon XL	Body	HVAC Control Module Manual																												V																															
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																											
C	2007	Yukon XL	Body	Lift Gate Module																																																											
C	2007	Yukon XL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2007	Yukon XL	Body	Park Assist Module																																							V	V	V																	
C	2007	Yukon XL	Body	Passenger Door Switch																																																											
C	2007	Yukon XL	Body	Passenger Presence System																																										V																
C	2007	Yukon XL	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2007	Yukon XL	Body	Rear Heated Seat Module																																		V				V																				
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																									
C	2007	Yukon XL	Body	Rollover Sensor																																																										
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																									V									V						
C	2007	Yukon XL	Body	Theft Deterrent Module																																																									
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																						
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V																																																						
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																						
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																								
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																						
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																							
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module	V			V																																																							
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																									
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																								
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2008	Sierra	Chassis	Electronic Suspension Control																																																											
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																											
C	2008	Sierra	Body	Amplifier (Bose)																																																											
C	2008	Sierra	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																																
C	2008	Sierra	Body	Body Control Module (aux.)																																																											
C	2008	Sierra	Body	Digital Radio Receiver																																																											
C	2008	Sierra	Body	Driver Door Switch																																																											
C	2008	Sierra	Body	HVAC Control Module Auto																												V	V																															
C	2008	Sierra	Body	HVAC Control Module Manual																													V																															
C	2008	Sierra	Body	Instrument Panel Cluster																																																											
C	2008	Sierra	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2008	Sierra	Body	Park Assist Module																																							V	V	V																	
C	2008	Sierra	Body	Passenger Door Switch																																																											
C	2008	Sierra	Body	Passenger Presence System																																									V																	
C	2008	Sierra	Body	Radio																																																										
C	2008	Sierra	Body	Rear Heated Seat Module																																		V				V																				
C	2008	Sierra	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2008	Sierra	Body	Rollover Sensor																																																								
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																									V									V				
C	2008	Sierra	Body	Theft Deterrent Module																																																							
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																				
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																				
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module	V			V																																																				
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																						
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																				
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2008	Yukon	Chassis	Electronic Brake Control Module																																																								
C	2008	Yukon	Chassis	Electronic Suspension Control																																																								
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																								
C	2008	Yukon	Body	Amplifier (Bose)																																																								
C	2008	Yukon	Body	Assist Step Controller																																																								
C	2008	Yukon	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																														
C	2008	Yukon	Body	Body Control Module (aux.)																																																								
C	2008	Yukon	Body	Digital Radio Receiver																																																								
C	2008	Yukon	Body	Driver Door Switch																																																								
C	2008	Yukon	Body	HVAC Control Module Auto																												V	V																												
C	2008	Yukon	Body	HVAC Control Module Manual																													V																												
C	2008	Yukon	Body	Instrument Panel Cluster																																																								
C	2008	Yukon	Body	Lift Gate Module																																																								
C	2008	Yukon	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																			
C	2008	Yukon	Body	Park Assist Module																																						V	V	V																
C	2008	Yukon	Body	Passenger Door Switch																																																								
C	2008	Yukon	Body	Passenger Presence System																																									V															
C	2008	Yukon	Body	Radio																																																								
C	2008	Yukon	Body	Rear Heated Seat Module																																	V				V																			
C	2008	Yukon	Body	Rear HVAC/RSA																																																								
C	2008	Yukon	Body	Rollover Sensor																																																								
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																									V									V				
C	2008	Yukon	Body	Theft Deterrent Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																				
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																	
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																						
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																								
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																									
C	2008	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																														
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																									
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																									
C	2008	Yukon Hybrid	Body	HVAC Control Module																												V	V																													
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
C	2008	Yukon Hybrid	Body	Lift Gate Module																																																									
C	2008	Yukon Hybrid	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
C	2008	Yukon Hybrid	Body	Park Assist Module																																						V	V	V																	
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																									
C	2008	Yukon Hybrid	Body	Passenger Presence System																																									V																
C	2008	Yukon Hybrid	Body	Radio																																																									
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																V				V																				
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																										
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																									V									V						
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																									
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																						
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																								
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																						
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module	V			V																																																						
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																								
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW														V																																											
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon XL	Body	Amplifier (Bose)																																																										
C	2008	Yukon XL	Body	Assist Step Controller																																																										
C	2008	Yukon XL	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																															
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2008	Yukon XL	Body	Digital Radio Receiver																																																										
C	2008	Yukon XL	Body	Driver Door Switch																																																										
C	2008	Yukon XL	Body	HVAC Control Module Auto																												V	V																													
C	2008	Yukon XL	Body	HVAC Control Module Manual																													V																													
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2008	Yukon XL	Body	Lift Gate Module																																																										
C	2008	Yukon XL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2008	Yukon XL	Body	Park Assist Module																																							V	V	V																
C	2008	Yukon XL	Body	Passenger Door Switch																																																									
C	2008	Yukon XL	Body	Passenger Presence System																																										V																
C	2008	Yukon XL	Body	Radio																																																								
C	2008	Yukon XL	Body	Rear Heated Seat Module																																	V				V																					
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																									
C	2008	Yukon XL	Body	Rollover Sensor																																																									
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																										V									V						
C	2008	Yukon XL	Body	Theft Deterrent Module																																																									
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																						
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module		V																																																								
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V																																																						
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V			V																																																						
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module		V																																																								
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V			V																																																						
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																								
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																						
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module		V																																																								
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																						
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																							
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																						
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual	V			V																																																						
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																												
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2009	Sierra	Chassis	Electronic Suspension Control																																																										
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																										
C	2009	Sierra	Body	Amplifier (Bose)																																																										
C	2009	Sierra	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2009	Sierra	Body	Body Control Module (aux.)																																																										
C	2009	Sierra	Body	Digital Radio Receiver																																																										
C	2009	Sierra	Body	Driver Door Switch																																																										
C	2009	Sierra	Body	HVAC Control Module Auto																												V	V																														

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2009	Sierra	Body	HVAC Control Module Manual																												V																												
C	2009	Sierra	Body	Instrument Panel Cluster																																																								
C	2009	Sierra	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																			
C	2009	Sierra	Body	Park Assist Module																																							V	V	V															
C	2009	Sierra	Body	Passenger Door Switch																																																							
C	2009	Sierra	Body	Passenger Presence System																																									V														
C	2009	Sierra	Body	Radio																																																							
C	2009	Sierra	Body	Rear Heated Seat Module																																	V				V																			
C	2009	Sierra	Body	Rear HVAC/RSA																																																							
C	2009	Sierra	Body	Rollover Sensor																																																							
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																									V									V					
C	2009	Sierra	Body	Theft Deterrent Module																																																							
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																				
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																		
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																						
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																								
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																								
C	2009	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																													
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																								
C	2009	Sierra Hybrid	Body	Driver Door Switch																																																								
C	2009	Sierra Hybrid	Body	HVAC Control Module																												V	V																												
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
C	2009	Sierra Hybrid	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																			
C	2009	Sierra Hybrid	Body	Park Assist Module																																							V	V	V															
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																																								
C	2009	Sierra Hybrid	Body	Passenger Presence System																																									V														
C	2009	Sierra Hybrid	Body	Radio																																																								
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																	V				V																			
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																								
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																									V									V					
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed	V			V																																																				
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed	V			V																																																				
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed		V																																																						
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																								
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																				
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																							
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																									
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed	V			V																																																							
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed	V			V																																																							
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed		V																																																									
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
C	2009	Yukon	Chassis	Electronic Brake Control Module																																																												
C	2009	Yukon	Chassis	Electronic Suspension Control																																																												
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																												
C	2009	Yukon	Body	Amplifier (Bose)																																																												
C	2009	Yukon	Body	Assist Step Controller																																																												
C	2009	Yukon	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2009	Yukon	Body	Body Control Module (aux.)																																																												
C	2009	Yukon	Body	Digital Radio Receiver																																																												
C	2009	Yukon	Body	Driver Door Switch																																																												
C	2009	Yukon	Body	HVAC Control Module Auto																												V	V																															
C	2009	Yukon	Body	HVAC Control Module Manual																													V																															
C	2009	Yukon	Body	Instrument Panel Cluster																																																												
C	2009	Yukon	Body	Left Side Object Detection Module																																								V					V													
C	2009	Yukon	Body	Lift Gate Module																																																												
C	2009	Yukon	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																					
C	2009	Yukon	Body	Park Assist Module																																							V	V	V																	
C	2009	Yukon	Body	Passenger Door Switch																																																												
C	2009	Yukon	Body	Passenger Presence System																																										V																	
C	2009	Yukon	Body	Radio																																																											
C	2009	Yukon	Body	Rear Heated Seat Module																																	V				V																						
C	2009	Yukon	Body	Rear HVAC/RSA																																																											
C	2009	Yukon	Body	Right Side Object Detection Module																																								V					V													
C	2009	Yukon	Body	Rollover Sensor																																																											
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																									V										V					
C	2009	Yukon	Body	Theft Deterrent Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																								
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																					
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																									
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																												
C	2009	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																											
C	2009	Yukon Hybrid	Body	Driver Door Switch																																																											
C	2009	Yukon Hybrid	Body	Heated Seat Module																																	V				V																					
C	2009	Yukon Hybrid	Body	HVAC Control Module																											V	V																														
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																							V				V													
C	2009	Yukon Hybrid	Body	Park Assist Module																																						V	V	V																	
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																																										
C	2009	Yukon Hybrid	Body	Passenger Presence System																																									V																
C	2009	Yukon Hybrid	Body	Radio																																																										
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																	V				V																					
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																							V				V													
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																										
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																									V									V						
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																										
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																							
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module		V																																																									
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																							
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																									
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																							
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module		V																																																									
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																							
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																									
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW														V																																													
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																											
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																											
C	2009	Yukon XL	Body	Amplifier (Bose)																																																											
C	2009	Yukon XL	Body	Assist Step Controller																																																											
C	2009	Yukon XL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																											
C	2009	Yukon XL	Body	Digital Radio Receiver																																																											
C	2009	Yukon XL	Body	Driver Door Switch																																																											
C	2009	Yukon XL	Body	HVAC Control Module Auto																												V	V																														
C	2009	Yukon XL	Body	HVAC Control Module Manual																													V																														
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																											
C	2009	Yukon XL	Body	Left Side Object Detection Module																																							V				V													
C	2009	Yukon XL	Body	Lift Gate Module																																																											
C	2009	Yukon XL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2009	Yukon XL	Body	Park Assist Module																																							V	V	V																
C	2009	Yukon XL	Body	Passenger Door Switch																																																									
C	2009	Yukon XL	Body	Passenger Presence System																																										V																
C	2009	Yukon XL	Body	Radio																																																								
C	2009	Yukon XL	Body	Rear Heated Seat Module																																	V			V																						
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																									
C	2009	Yukon XL	Body	Right Side Object Detection Module																																							V					V													
C	2009	Yukon XL	Body	Rollover Sensor																																																									
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																									V										V						
C	2009	Yukon XL	Body	Theft Deterrent Module																																																									
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V			V																																																						
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																								
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																							
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																							
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																									
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																											
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																											
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																													
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2010	Sierra	Chassis	Electronic Suspension Control																																																											
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																											
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Sierra	Body	Amplifier (Bose)																																																											
C	2010	Sierra	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
C	2010	Sierra	Body	Body Control Module (aux.)																																																											
C	2010	Sierra	Body	Digital Radio Receiver																																																											
C	2010	Sierra	Body	Driver Door Switch																																																											
C	2010	Sierra	Body	HVAC Control Module Auto																												V	V																														
C	2010	Sierra	Body	HVAC Control Module Manual																													V																														
C	2010	Sierra	Body	Instrument Panel Cluster																																																											
C	2010	Sierra	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
C	2010	Sierra	Body	Park Assist Module																																							V	V	V																	

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2010	Sierra	Body	Passenger Door Switch																																																										
C	2010	Sierra	Body	Passenger Presence System																																									V																	
C	2010	Sierra	Body	Radio																																																									
C	2010	Sierra	Body	Rear Heated Seat Module																																	V				V																					
C	2010	Sierra	Body	Rear HVAC/RSA																																																										
C	2010	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2010	Sierra	Body	Theft Deterrent Module																																																										
C	2010	Sierra Hybrid	Powertrain	Engine Control Module	V			V																																																							
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																						V																																				
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module		V																																																								
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																										
C	2010	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																										
C	2010	Sierra Hybrid	Body	Driver Door Switch																																																										
C	2010	Sierra Hybrid	Body	Heated Seat Module																																	V				V																					
C	2010	Sierra Hybrid	Body	HVAC Control Module																												V	V																													
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
C	2010	Sierra Hybrid	Body	Park Assist Module																																							V	V	V																	
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																																										
C	2010	Sierra Hybrid	Body	Passenger Presence System																																									V																	
C	2010	Sierra Hybrid	Body	Radio																																																										
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																	V				V																					
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																							
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																									
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
C	2010	Yukon	Chassis	Electronic Brake Control Module																																																											
C	2010	Yukon	Chassis	Electronic Suspension Control																																																											
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Yukon	Body	Amplifier (Bose)																																																										
C	2010	Yukon	Body	Assist Step Controller																																																										
C	2010	Yukon	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2010	Yukon	Body	Body Control Module (aux.)																																																										
C	2010	Yukon	Body	Digital Radio Receiver																																																											
C	2010	Yukon	Body	Driver Door Switch																																																										
C	2010	Yukon	Body	HVAC Control Module Auto																												V	V																														
C	2010	Yukon	Body	HVAC Control Module Manual																													V																														
C	2010	Yukon	Body	Instrument Panel Cluster																																																										
C	2010	Yukon	Body	Left Side Object Detection Module																																								V					V													
C	2010	Yukon	Body	Lift Gate Module																																																										
C	2010	Yukon	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				
C	2010	Yukon	Body	Park Assist Module																																							V	V	V																	
C	2010	Yukon	Body	Passenger Door Switch																																																										
C	2010	Yukon	Body	Passenger Presence System																																										V																
C	2010	Yukon	Body	Radio																																																										
C	2010	Yukon	Body	Rear Heated Seat Module																																	V				V																					
C	2010	Yukon	Body	Rear HVAC/RSA																																																										
C	2010	Yukon	Body	Right Side Object Detection Module																																								V					V													
C	2010	Yukon	Body	Supplemental Inflatable Restraint																																																										
C	2010	Yukon	Body	Theft Deterrent Module																																																										
C	2010	Yukon Hybrid	Powertrain	Engine Control Module	V			V																																																							
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																						V																																				
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module		V																																																								
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																										
C	2010	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2010	Yukon Hybrid	Body	Driver Door Switch																																																										
C	2010	Yukon Hybrid	Body	Heated Seat Module																																	V				V																					
C	2010	Yukon Hybrid	Body	HVAC Control Module																												V	V																														
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																								V					V													
C	2010	Yukon Hybrid	Body	Lift Gate Module																																																										
C	2010	Yukon Hybrid	Body	Park Assist Module																																							V	V	V																	
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																																										
C	2010	Yukon Hybrid	Body	Passenger Presence System																																										V																
C	2010	Yukon Hybrid	Body	Radio																																																										
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																	V				V																					
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																								V					V													
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																										
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																						
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																								
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																						
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																										
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW														V																																											
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2010	Yukon XL	Body	Amplifier (Bose)																																																										
C	2010	Yukon XL	Body	Assist Step Controller																																																										
C	2010	Yukon XL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2010	Yukon XL	Body	Digital Radio Receiver																																																										
C	2010	Yukon XL	Body	Driver Door Switch																																																										
C	2010	Yukon XL	Body	HVAC Control Module Auto																												V	V																														
C	2010	Yukon XL	Body	HVAC Control Module Manual																													V																														
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2010	Yukon XL	Body	Left Side Object Detection Module																																								V					V													
C	2010	Yukon XL	Body	Lift Gate Module																																																										
C	2010	Yukon XL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				
C	2010	Yukon XL	Body	Park Assist Module																																							V	V	V																	
C	2010	Yukon XL	Body	Passenger Door Switch																																																										
C	2010	Yukon XL	Body	Passenger Presence System																																										V																
C	2010	Yukon XL	Body	Radio																																																										
C	2010	Yukon XL	Body	Rear Heated Seat Module																																	V				V																					
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2010	Yukon XL	Body	Right Side Object Detection Module																																								V					V													
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
C	2010	Yukon XL	Body	Theft Deterrent Module																																																										
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module				V																																																						
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module		V																																																									
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																										
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module		V																																																								
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2008	ALL	Chassis	Electronic Brake Control Module																																																										
D	2008	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
D	2008	ALL	Body	Body Control Module (aux.)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
D	2008	ALL	Body	Headlamp Control Module																																																										
D	2008	ALL	Body	HVAC Control Module Auto																																																											
D	2008	ALL	Body	Instrument Panel Cluster																																																											
D	2008	ALL	Body	Park Assist Module																																							V	V	V																	
D	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2008	ALL	Body	Supplemental Inflatable Restraint																																										V									V						
D	2008	ALL	Body	Theft Deterrent Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module				V																																																							
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module		V																																																									
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																											
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																											
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module		V																																																									
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																											
D	2009	ALL	Chassis	Electronic Brake Control Module																																																											
D	2009	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
D	2009	ALL	Body	Body Control Module (aux.)																																																											
D	2009	ALL	Body	Headlamp Control Module																																																											
D	2009	ALL	Body	HVAC Control Module Auto																																																											
D	2009	ALL	Body	Instrument Panel Cluster																																																											
D	2009	ALL	Body	Park Assist Module																																							V	V	V																	
D	2009	ALL	Body	Remote Control Door Lock Receiver																																																											
D	2009	ALL	Body	Supplemental Inflatable Restraint																																										V									V						
D	2009	ALL	Body	Theft Deterrent Module																																																											
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module				V																																																							
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module		V																																																									
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																												
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module	V			V																																																							
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module		V																																																									
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																												
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																												
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module		V																																																									
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																												
D	2010	ALL	Chassis	Electronic Brake Control Module																																																												
D	2010	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
D	2010	ALL	Body	Body Control Module (aux.)																																																											
D	2010	ALL	Body	Headlamp Control Module																																																											
D	2010	ALL	Body	HVAC Control Module Auto																																																											
D	2010	ALL	Body	Instrument Panel Cluster																																																											
D	2010	ALL	Body	Park Assist Module																																							V	V	V																	
D	2010	ALL	Body	Remote Control Door Lock Receiver																																																											
D	2010	ALL	Body	Supplemental Inflatable Restraint																																										V									V						
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2004	Express/Savana	Chassis	VSES																																																									
G	2004	Express/Savana	Body	Body Control Module																																																									
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2004	Express/Savana	Body	OnStar																																																									
G	2004	Express/Savana	Body	Base Radio																																																									
G	2004	Express/Savana	Body	Uplevel Radio																																																									
G	2004	Express/Savana	Body	Remote Function Actuation																																																									
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2004	Express Access/Savana Pro	Chassis	VSES																																																									
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2004	Express Access/Savana Pro	Body	OnStar																																																									
G	2004	Express Access/Savana Pro	Body	Base Radio																																																									
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2005	Express/Savana	Chassis	VSES																																																									
G	2005	Express/Savana	Body	Body Control Module																																																									
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2005	Express/Savana	Body	Base Radio																																																									
G	2005	Express/Savana	Body	Uplevel Radio																																																									
G	2005	Express/Savana	Body	Remote Function Actuation																																																									
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2005	Express Access/Savana Pro	Chassis	VSES																																																									
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2005	Express Access/Savana Pro	Body	Base Radio																																																									
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2006	Express/Savana	Chassis	VSES																																																										
G	2006	Express/Savana	Body	Body Control Module																																																										
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2006	Express/Savana	Body	Passenger Presence System																																																										
G	2006	Express/Savana	Body	Base Radio																																																										
G	2006	Express/Savana	Body	Uplevel Radio																																																										
G	2006	Express/Savana	Body	Remote Function Actuation																																																										
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																					
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2006	Express Access/Savana Pro	Chassis	VSES																																																										
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2006	Express Access/Savana Pro	Body	Base Radio																																																										
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																						
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																											
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V									V																																																
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																											
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																											
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2007	Express/Savana	Body	Body Control Module																																																											
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																											
G	2007	Express/Savana	Body	Passenger Presence System																																																											
G	2007	Express/Savana	Body	Base Radio																																																											
G	2007	Express/Savana	Body	Uplevel Radio																																																											
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																						
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V									V																																																

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2007	Express Access/Savana Pro	Body	Radio																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V																																																									
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V																																																									
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																											
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2008	Express/Savana	Body	Passenger Presence System																																									V	V																	
G	2008	Express/Savana	Body	Radio																																																										
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express/Savana	Body	Rollover Sensor																																																										
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																								V									V								
G	2008	Express/Savana	Body	Theft Deterrent Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V																																																									
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V																																																									
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2008	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V																
G	2008	Express Access/Savana Pro	Body	Radio																																																											
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V							
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																								
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																								
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																								
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																								
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																													
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2009	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																	
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2009	Express/Savana	Body	Passenger Presence System																																									V	V																
G	2009	Express/Savana	Body	Radio																																																											
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2009	Express/Savana	Body	Rollover Sensor																																																												
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																									V									V							
G	2009	Express/Savana	Body	Theft Deterrent Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																								
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																								
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																								
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																								
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																													
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2009	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																	
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V																
G	2009	Express Access/Savana Pro	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V						
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module		V																																																										
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																													
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																	
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2010	Express/Savana	Body	Passenger Presence System																																									V	V																		
G	2010	Express/Savana	Body	Radio																																																											
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2010	Express/Savana	Body	Rollover Sensor																																																											
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																									V									V						
G	2010	Express/Savana	Body	Theft Deterrent Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																									
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module		V																																																									
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																													
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																	

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V															
G	2010	Express Access/Savana Pro	Body	Radio																																																										
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V						
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2004	Express/Savana	Chassis	VSES																																																										
H	2004	Express/Savana	Body	Body Control Module																																																										
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2004	Express/Savana	Body	OnStar																																																										
H	2004	Express/Savana	Body	Base Radio																																																										
H	2004	Express/Savana	Body	Uplevel Radio																																																										
H	2004	Express/Savana	Body	Remote Function Actuation																																																										
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2004	Express Access/Savana Pro	Chassis	VSES																																																										
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2004	Express Access/Savana Pro	Body	OnStar																																																										
H	2004	Express Access/Savana Pro	Body	Base Radio																																																										
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2005	Express/Savana	Chassis	VSES																																																										
H	2005	Express/Savana	Body	Body Control Module																																																										
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2005	Express/Savana	Body	Base Radio																																																										
H	2005	Express/Savana	Body	Uplevel Radio																																																										
H	2005	Express/Savana	Body	Remote Function Actuation																																																										
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2005	Express Access/Savana Pro	Chassis	VSES																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2005	Express Access/Savana Pro	Body	Base Radio																																																									
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																									
H	2006	Express/Savana	Chassis	VSES																																																									
H	2006	Express/Savana	Body	Body Control Module																																																									
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2006	Express/Savana	Body	Passenger Presence System																																																									
H	2006	Express/Savana	Body	Base Radio																																																									
H	2006	Express/Savana	Body	Uplevel Radio																																																									
H	2006	Express/Savana	Body	Remote Function Actuation																																																									
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
H	2006	Express Access/Savana Pro	Chassis	VSES																																																									
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2006	Express Access/Savana Pro	Body	Base Radio																																																									
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2007	Express/Savana	Body	Body Control Module																																																									
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																									
H	2007	Express/Savana	Body	Passenger Presence System																																																									
H	2007	Express/Savana	Body	Base Radio																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2007	Express/Savana	Body	Uplevel Radio																																																										
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2007	Express Access/Savana Pro	Body	Base Radio																																																										
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V																																																									
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V																																																									
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																												
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2008	Express/Savana	Body	Passenger Presence System																																									V	V																
H	2008	Express/Savana	Body	Radio																																																										
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express/Savana	Body	Rollover Sensor																																																										
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																									V									V								
H	2008	Express/Savana	Body	Theft Deterrent Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V																																																									
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V																																																									
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																												
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2008	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V																
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V							
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																							
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																							
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																												
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2009	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																	
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2009	Express/Savana	Body	Passenger Presence System																																									V	V																
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
H	2009	Express/Savana	Body	Rollover Sensor																																																											
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																									V									V							
H	2009	Express/Savana	Body	Theft Deterrent Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																							
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																							
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																												
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2009	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																	
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V																
H	2009	Express Access/Savana Pro	Body	Radio																																																											
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																											
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V							
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																								
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																								
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																												
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2010	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2010	Express/Savana	Body	Passenger Presence System																																										V	V															
H	2010	Express/Savana	Body	Radio																																																										
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
H	2010	Express/Savana	Body	Rollover Sensor																																																											
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																								V									V							
H	2010	Express/Savana	Body	Theft Deterrent Module																																																											
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																								
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																													
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2010	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																								V	V																		
H	2010	Express Access/Savana Pro	Body	Radio																																																											
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																											
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								V									V							
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case											V																																																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case											V																																																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case											V																																																	
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case											V																																																	
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case											V																																																	
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable											V																																																	
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control											V																																																	

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable											V																																																	
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable											V																																																	
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control											V																																																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable											V																																																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable											V																																																	
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control											V																																																	
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case											V																																																	
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case											V																																																	
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable											V																																																	
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable											V																																																	
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
K	2004	ALL	Chassis	ESC																																																											
K	2004	ALL	Chassis	Rear Wheel Steering																																																												
K	2004	ALL	Chassis	Tire Pressure Monitor																																																												
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																												
K	2004	ALL	Chassis	VSES																																																											
K	2004	ALL	Body	Amplifier (Bose)																																																												
K	2004	ALL	Body	Body Control Module																																																											
K	2004	ALL	Body	CD Changer																																																											
K	2004	ALL	Body	Chime																																																											
K	2004	ALL	Body	Driver Door Module																																																											
K	2004	ALL	Body	Driver Seat Module																																																												
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2004	ALL	Body	Instrument Panel Cluster																																																												
K	2004	ALL	Body	OnStar																																																											
K	2004	ALL	Body	Passenger Door Module																																																												
K	2004	ALL	Body	Passenger Presence System																																																												
K	2004	ALL	Body	Radio Base																																																												
K	2004	ALL	Body	Radio Uplevel																																																												
K	2004	ALL	Body	Radio Navigation																																																												
K	2004	ALL	Body	Rear Aux. Climate Module																																																												
K	2004	ALL	Body	Rear HVAC																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2004	ALL	Body	Rear Seat Audio																																																											
K	2004	ALL	Body	Rear Seat Entertainment																																																											
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2004	ALL	Body	Vehicle Theft Deterrent																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC											V																																																
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC											V																																																
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC											V																																																
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case											V																																																
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case											V																																																
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																											
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case											V																																																
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable											V																																																
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control											V																																																
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable											V																																																
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable											V																																																
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control											V																																																
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable											V																																																
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable											V																																																
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control											V																																																
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case											V																																																
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																											
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																											
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable											V																																																
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable											V																																																
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2005	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC											V																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC											V																																														
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case											V																																														
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case											V																																														
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case											V																																																
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable											V																																																	
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control											V																																																	
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable											V																																																	
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable											V																																																	
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control											V																																																	
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable											V																																																	
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable											V																																																	
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control											V																																																	
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable											V																																																	
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable											V																																																	
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module					V																																																							
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module			V																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case											V																																																	
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module					V																																																							
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module			V																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case											V																																																	
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed			V																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable											V																																																		
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable											V																																																		
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																													
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																													
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																														
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																													
K	2006	ALL	Chassis	ESC																																																													
K	2006	ALL	Chassis	Tire Pressure Monitor																																																													
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																													
K	2006	ALL	Chassis	VSES																																																													
K	2006	ALL	Body	Amplifier (Bose)																																																													
K	2006	ALL	Body	Body Control Module																																																													
K	2006	ALL	Body	CD Changer																																																													
K	2006	ALL	Body	Chime																																																													
K	2006	ALL	Body	Disc Player and Video Display																																																													
K	2006	ALL	Body	Driver Door Module																																																													
K	2006	ALL	Body	Driver Seat Module																																																													
K	2006	ALL	Body	Generator Battery Control Module																																																													
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																													

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2006	ALL	Body	Instrument Panel Cluster																																																											
K	2006	ALL	Body	Passenger Door Module																																																											
K	2006	ALL	Body	Passenger Presence System																																																											
K	2006	ALL	Body	Base Radio																																																											
K	2006	ALL	Body	Uplevel Radio																																																											
K	2006	ALL	Body	Navigation Radio																																																											
K	2006	ALL	Body	Rear Aux. Climate Module																																																											
K	2006	ALL	Body	Rear HVAC																																																											
K	2006	ALL	Body	Rear Seat Audio																																																											
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2006	ALL	Body	Vehicle Theft Deterrent																																																											
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																											
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V																																																							
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																																
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module				V																																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																																
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																								
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module											V																																																
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																								
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																										
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module											V																																																
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																								
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																																
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module				V																																																								
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module											V																																																
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module	V			V																																																								
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module											V																																																
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module				V																																																								
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																																
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																								
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																																

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Sierra	Chassis	Electronic Suspension Control																																																									
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																									
K	2007	Sierra	Body	Amplifier (Bose)																																																									
K	2007	Sierra	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																														
K	2007	Sierra	Body	Body Control Module (aux.)																																																									
K	2007	Sierra	Body	Digital Radio Receiver																																																									
K	2007	Sierra	Body	Driver Door Switch																																																									
K	2007	Sierra	Body	HVAC Control Module Auto																												V	V																												
K	2007	Sierra	Body	HVAC Control Module Manual																													V																												
K	2007	Sierra	Body	Instrument Panel Cluster																																																									
K	2007	Sierra	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																			
K	2007	Sierra	Body	Park Assist Module																																							V	V	V																
K	2007	Sierra	Body	Passenger Door Switch																																																									
K	2007	Sierra	Body	Passenger Presence System																																										V															
K	2007	Sierra	Body	Radio																																																									
K	2007	Sierra	Body	Rear Heated Seat Module																																		V				V																			
K	2007	Sierra	Body	Rear HVAC/RSA																																																									
K	2007	Sierra	Body	Rollover Sensor																																																									
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																										V									V						
K	2007	Sierra	Body	Theft Deterrent Module																																																									
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module				V																																																					
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																														
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module				V																																																					
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module											V																																														
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module				V																																																					
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																							
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module				V																																																					
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																														
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Yukon	Chassis	Electronic Suspension Control																																																									
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																									
K	2007	Yukon	Body	Amplifier (Bose)																																																									
K	2007	Yukon	Body	Assist Step Controller																																																									
K	2007	Yukon	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																														
K	2007	Yukon	Body	Body Control Module (aux.)																																																									
K	2007	Yukon	Body	Digital Radio Receiver																																																									
K	2007	Yukon	Body	Driver Door Switch																																																									
K	2007	Yukon	Body	HVAC Control Module Auto																												V	V																												
K	2007	Yukon	Body	HVAC Control Module Manual																													V																												
K	2007	Yukon	Body	Instrument Panel Cluster																																																									
K	2007	Yukon	Body	Lift Gate Module																																																									
K	2007	Yukon	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																			
K	2007	Yukon	Body	Park Assist Module																																							V	V	V																

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2007	Yukon	Body	Passenger Door Switch																																																									
K	2007	Yukon	Body	Passenger Presence System																																																									
K	2007	Yukon	Body	Radio																																																									
K	2007	Yukon	Body	Rear Heated Seat Module																																																									
K	2007	Yukon	Body	Rear HVAC/RSA																																																									
K	2007	Yukon	Body	Rollover Sensor																																																									
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																																									
K	2007	Yukon	Body	Theft Deterrent Module																																																									
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																									
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																									
K	2007	Yukon XL	Body	Amplifier (Bose)																																																									
K	2007	Yukon XL	Body	Assist Step Controller																																																									
K	2007	Yukon XL	Body	Body Control Module														V	V	V	V	V	V	V		V	V		V																																
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																									
K	2007	Yukon XL	Body	Digital Radio Receiver																																																									
K	2007	Yukon XL	Body	Driver Door Switch																																																									
K	2007	Yukon XL	Body	HVAC Control Module Auto																											V	V																													
K	2007	Yukon XL	Body	HVAC Control Module Manual																												V																													
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																									
K	2007	Yukon XL	Body	Lift Gate Module																																																									
K	2007	Yukon XL	Body	Memory Seat Module																													V	V	V	V	V	V	V	V																					
K	2007	Yukon XL	Body	Park Assist Module																																					V	V	V																		
K	2007	Yukon XL	Body	Passenger Door Switch																																																									
K	2007	Yukon XL	Body	Passenger Presence System																																									V																
K	2007	Yukon XL	Body	Radio																																																									
K	2007	Yukon XL	Body	Rear Heated Seat Module																																V				V																					
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																									
K	2007	Yukon XL	Body	Rollover Sensor																																																									
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																									V									V							
K	2007	Yukon XL	Body	Theft Deterrent Module																																																									
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																					

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																															
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V																																																						
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																															
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V			V																																																						
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module											V																																															
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																								
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module											V																																															
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																						
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																															
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																						
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module											V																																															
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module	V			V																																																						
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																								
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module											V																																															
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																							
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																															
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																															
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Sierra	Chassis	Electronic Suspension Control																																																										
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2008	Sierra	Body	Amplifier (Bose)																																																										
K	2008	Sierra	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V		V																																
K	2008	Sierra	Body	Body Control Module (aux.)																																																										
K	2008	Sierra	Body	Digital Radio Receiver																																																										
K	2008	Sierra	Body	Driver Door Switch																																																										
K	2008	Sierra	Body	HVAC Control Module Auto																												V	V																													
K	2008	Sierra	Body	HVAC Control Module Manual																													V																													
K	2008	Sierra	Body	Instrument Panel Cluster																																																										
K	2008	Sierra	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
K	2008	Sierra	Body	Park Assist Module																																							V	V	V																	
K	2008	Sierra	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2008	Sierra	Body	Passenger Presence System																																										V														
K	2008	Sierra	Body	Radio																																																							
K	2008	Sierra	Body	Rear Heated Seat Module																																	V				V																			
K	2008	Sierra	Body	Rear HVAC/RSA																																																							
K	2008	Sierra	Body	Rollover Sensor																																																							
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																										V									V					
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																							
K	2008	Sierra	Body	Theft Deterrent Module																																																							
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																				
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																							
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																							
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																												
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																				
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																							
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																							
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module	V			V																																																				
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																							
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																					
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																			
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																							
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																												
K	2008	Yukon	Chassis	Electronic Brake Control Module																																																							
K	2008	Yukon	Chassis	Electronic Suspension Control																																																							
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																							
K	2008	Yukon	Body	Amplifier (Bose)																																																						
K	2008	Yukon	Body	Assist Step Controller																																																						
K	2008	Yukon	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																													
K	2008	Yukon	Body	Body Control Module (aux.)																																																						
K	2008	Yukon	Body	Digital Radio Receiver																																																						
K	2008	Yukon	Body	Driver Door Switch																																																						
K	2008	Yukon	Body	HVAC Control Module Auto																												V	V																										
K	2008	Yukon	Body	HVAC Control Module Manual																													V																										
K	2008	Yukon	Body	Instrument Panel Cluster																																																						
K	2008	Yukon	Body	Lift Gate Module																																																						
K	2008	Yukon	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																		
K	2008	Yukon	Body	Park Assist Module																																						V	V	V															
K	2008	Yukon	Body	Passenger Door Switch																																																						
K	2008	Yukon	Body	Passenger Presence System																																									V														
K	2008	Yukon	Body	Radio																																																						
K	2008	Yukon	Body	Rear Heated Seat Module																																	V				V																		
K	2008	Yukon	Body	Rear HVAC/RSA																																																						
K	2008	Yukon	Body	Rollover Sensor																																																						
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																									V									V					
K	2008	Yukon	Body	Theft Deterrent Module																																																						
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																			
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																						
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																						
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																						
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																															
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																						

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module											V																																															
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																											
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																											
K	2008	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																																
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																											
K	2008	Yukon Hybrid	Body	Driver Door Switch																																																											
K	2008	Yukon Hybrid	Body	HVAC Control Module																												V	V																															
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
K	2008	Yukon Hybrid	Body	Lift Gate Module																																																											
K	2008	Yukon Hybrid	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																						
K	2008	Yukon Hybrid	Body	Park Assist Module																																							V	V	V																		
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																																											
K	2008	Yukon Hybrid	Body	Passenger Presence System																																										V																	
K	2008	Yukon Hybrid	Body	Radio																																																											
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																	V				V																						
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																											
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																									V									V							
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																								
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																																
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																								
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																										
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module											V																																																
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																								
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																																
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module	V			V																																																								
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module		V																																																										
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																								
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																																
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																																
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW														V																																													

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																									
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																									
K	2008	Yukon XL	Body	Amplifier (Bose)																																																									
K	2008	Yukon XL	Body	Assist Step Controller																																																									
K	2008	Yukon XL	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																														
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																									
K	2008	Yukon XL	Body	Digital Radio Receiver																																																									
K	2008	Yukon XL	Body	Driver Door Switch																																																									
K	2008	Yukon XL	Body	HVAC Control Module Auto																												V	V																												
K	2008	Yukon XL	Body	HVAC Control Module Manual																													V																												
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																									
K	2008	Yukon XL	Body	Lift Gate Module																																																									
K	2008	Yukon XL	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																			
K	2008	Yukon XL	Body	Park Assist Module																																							V	V	V																
K	2008	Yukon XL	Body	Passenger Door Switch																																																									
K	2008	Yukon XL	Body	Passenger Presence System																																										V															
K	2008	Yukon XL	Body	Radio																																																									
K	2008	Yukon XL	Body	Rear Heated Seat Module																																	V				V																				
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																									
K	2008	Yukon XL	Body	Rollover Sensor																																																									
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																										V									V						
K	2008	Yukon XL	Body	Theft Deterrent Module																																																									
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																					
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module										V																																															
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module		V																																																							
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module				V																																																					
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module										V																																															
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module	V			V																																																					
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module										V																																															
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module		V																																																							
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto	V			V																																																					
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul	V			V																																																					
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																							
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module										V																																															
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																					
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module										V																																															
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed		V																																																							
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																									
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																					
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module										V																																															
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																									
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module										V																																															
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																						

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																																
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																								
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																																	
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																																	
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed		V																																																									
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																													
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2009	Sierra	Chassis	Electronic Suspension Control																																																												
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																												
K	2009	Sierra	Body	Amplifier (Bose)																																																												
K	2009	Sierra	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																	
K	2009	Sierra	Body	Body Control Module (aux.)																																																												
K	2009	Sierra	Body	Digital Radio Receiver																																																												
K	2009	Sierra	Body	Driver Door Switch																																																												
K	2009	Sierra	Body	HVAC Control Module Auto																												V	V																															
K	2009	Sierra	Body	HVAC Control Module Manual																													V																															
K	2009	Sierra	Body	Instrument Panel Cluster																																																												
K	2009	Sierra	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																					
K	2009	Sierra	Body	Park Assist Module																																							V	V	V																		
K	2009	Sierra	Body	Passenger Door Switch																																																											
K	2009	Sierra	Body	Passenger Presence System																																										V																
K	2009	Sierra	Body	Radio																																																										
K	2009	Sierra	Body	Rear Heated Seat Module																																	V				V																					
K	2009	Sierra	Body	Rear HVAC/RSA																																																											
K	2009	Sierra	Body	Rollover Sensor																																																											
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																										V										V					
K	2009	Sierra	Body	Theft Deterrent Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																					
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module											V																																																	
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																												
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																									
K	2009	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																									
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																									
K	2009	Sierra Hybrid	Body	Driver Door Switch																																																									
K	2009	Sierra Hybrid	Body	HVAC Control Module																												V	V																													
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																									
K	2009	Sierra Hybrid	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
K	2009	Sierra Hybrid	Body	Park Assist Module																																						V	V	V																	
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																																									
K	2009	Sierra Hybrid	Body	Passenger Presence System																																									V																
K	2009	Sierra Hybrid	Body	Radio																																																									
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																V				V																					
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																									
K	2009	Sierra Hybrid	Body	Rollover Sensor																																																									
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																									
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																									V										V					
K	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																									
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																						
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed		V																																																							
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																									
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																														
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module	V			V																																																						
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module											V																																														
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																														
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																						
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																														
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed		V																																																								
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																														
K	2009	Yukon	Chassis	Electronic Brake Control Module																																																										
K	2009	Yukon	Chassis	Electronic Suspension Control																																																										
K	2009	Yukon	Chassis	Trailer Brake Control Module																																																										
K	2009	Yukon	Body	Amplifier (Bose)																																																										
K	2009	Yukon	Body	Assist Step Controller																																																										
K	2009	Yukon	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2009	Yukon	Body	Body Control Module (aux.)																																																										
K	2009	Yukon	Body	Digital Radio Receiver																																																										
K	2009	Yukon	Body	Driver Door Switch																																																										
K	2009	Yukon	Body	HVAC Control Module Auto																												V	V																													
K	2009	Yukon	Body	HVAC Control Module Manual																													V																													

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2009	Yukon	Body	Instrument Panel Cluster																																																										
K	2009	Yukon	Body	Left Side Object Detection Module																																								V					V													
K	2009	Yukon	Body	Lift Gate Module																																																									
K	2009	Yukon	Body	Memory Seat Module																													V	V	V	V	V	V	V	V	V																					
K	2009	Yukon	Body	Park Assist Module																																						V	V	V																	
K	2009	Yukon	Body	Passenger Door Switch																																																									
K	2009	Yukon	Body	Passenger Presence System																																									V																
K	2009	Yukon	Body	Radio																																																									
K	2009	Yukon	Body	Rear Heated Seat Module																																V				V																					
K	2009	Yukon	Body	Rear HVAC/RSA																																																									
K	2009	Yukon	Body	Right Side Object Detection Module																																						V					V													
K	2009	Yukon	Body	Rollover Sensor																																																									
K	2009	Yukon	Body	Supplemental Inflatable Restraint																																									V											V					
K	2009	Yukon	Body	Theft Deterrent Module																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module	V			V																																																					
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																							V																																		
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module		V																																																							
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module										V																																															
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Yukon Hybrid	Body	Driver Door Switch																																																										
K	2009	Yukon Hybrid	Body	Heated Seat Module																																V				V																					
K	2009	Yukon Hybrid	Body	HVAC Control Module																											V	V																														
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																								V					V													
K	2009	Yukon Hybrid	Body	Park Assist Module																																						V	V	V																	
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																																										
K	2009	Yukon Hybrid	Body	Passenger Presence System																																									V																
K	2009	Yukon Hybrid	Body	Radio																																																										
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																V				V																					
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																								V					V													
K	2009	Yukon Hybrid	Body	Rollover Sensor																																																										
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																									V											V					
K	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module	V			V																																																						
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module		V																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module											V																																															
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module	V			V																																																						
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																								
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module											V																																															
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module	V			V																																																						
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module		V																																																								
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module											V																																															
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																															
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																							
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																																
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																																
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW														V																																												
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																											
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																											
K	2009	Yukon XL	Body	Amplifier (Bose)																																																											
K	2009	Yukon XL	Body	Assist Step Controller																																																											
K	2009	Yukon XL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																											
K	2009	Yukon XL	Body	Digital Radio Receiver																																																											
K	2009	Yukon XL	Body	Driver Door Switch																																																											
K	2009	Yukon XL	Body	HVAC Control Module Auto																												V	V																														
K	2009	Yukon XL	Body	HVAC Control Module Manual																													V																														
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																											
K	2009	Yukon XL	Body	Left Side Object Detection Module																																								V					V													
K	2009	Yukon XL	Body	Lift Gate Module																																																											
K	2009	Yukon XL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																					
K	2009	Yukon XL	Body	Park Assist Module																																							V	V	V																	
K	2009	Yukon XL	Body	Passenger Door Switch																																																											
K	2009	Yukon XL	Body	Passenger Presence System																																										V																	
K	2009	Yukon XL	Body	Radio																																																										
K	2009	Yukon XL	Body	Rear Heated Seat Module																																	V				V																					
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																											
K	2009	Yukon XL	Body	Right Side Object Detection Module																																								V					V													
K	2009	Yukon XL	Body	Rollover Sensor																																																											
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																									V											V					
K	2009	Yukon XL	Body	Theft Deterrent Module																																																											
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																																
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto	V			V																																																							
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual	V			V																																																							

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module		V																																																								
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module											V																																															
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module											V																																																
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module			V																																																								
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module											V																																																
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																								
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																																	
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																								
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																																	
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																																	
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																													
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2010	Sierra	Chassis	Electronic Suspension Control																																																												
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																												
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra	Body	Amplifier (Bose)																																																												
K	2010	Sierra	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
K	2010	Sierra	Body	Body Control Module (aux.)																																																											
K	2010	Sierra	Body	Digital Radio Receiver																																																												
K	2010	Sierra	Body	Driver Door Switch																																																												
K	2010	Sierra	Body	HVAC Control Module Auto																												V	V																															
K	2010	Sierra	Body	HVAC Control Module Manual																													V																															
K	2010	Sierra	Body	Instrument Panel Cluster																																																												
K	2010	Sierra	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																						
K	2010	Sierra	Body	Park Assist Module																																						V	V	V																			
K	2010	Sierra	Body	Passenger Door Switch																																																												
K	2010	Sierra	Body	Passenger Presence System																																									V																			
K	2010	Sierra	Body	Radio																																																											
K	2010	Sierra	Body	Rear Heated Seat Module																																	V				V																						
K	2010	Sierra	Body	Rear HVAC/RSA																																																												
K	2010	Sierra	Body	Supplemental Inflatable Restraint																																																												
K	2010	Sierra	Body	Theft Deterrent Module																																																												
K	2010	Sierra Hybrid	Powertrain	Engine Control Module	V			V																																																								
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																							V																																			
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module		V																																																								
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module											V																																															
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Sierra Hybrid	Body	Driver Door Switch																																																										
K	2010	Sierra Hybrid	Body	Heated Seat Module																																	V				V																						
K	2010	Sierra Hybrid	Body	HVAC Control Module																												V	V																													
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Sierra Hybrid	Body	Park Assist Module																																							V	V	V																	
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																																										
K	2010	Sierra Hybrid	Body	Passenger Presence System																																										V																
K	2010	Sierra Hybrid	Body	Radio																																																										
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																	V				V																						
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																							
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																									
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module											V																																																
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																																
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																																
K	2010	Yukon	Chassis	Electronic Brake Control Module																																																											
K	2010	Yukon	Chassis	Electronic Suspension Control																																																											
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Yukon	Body	Amplifier (Bose)																																																											
K	2010	Yukon	Body	Assist Step Controller																																																											
K	2010	Yukon	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2010	Yukon	Body	Body Control Module (aux.)																																																											
K	2010	Yukon	Body	Digital Radio Receiver																																																											
K	2010	Yukon	Body	Driver Door Switch																																																											
K	2010	Yukon	Body	HVAC Control Module Auto																												V	V																														
K	2010	Yukon	Body	HVAC Control Module Manual																													V																															

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2010	Yukon	Body	Instrument Panel Cluster																																																										
K	2010	Yukon	Body	Left Side Object Detection Module																																								V					V													
K	2010	Yukon	Body	Lift Gate Module																																																									
K	2010	Yukon	Body	Memory Seat Module																													V	V	V	V	V	V	V	V	V																					
K	2010	Yukon	Body	Park Assist Module																																						V	V	V																	
K	2010	Yukon	Body	Passenger Door Switch																																																									
K	2010	Yukon	Body	Passenger Presence System																																									V																
K	2010	Yukon	Body	Radio																																																									
K	2010	Yukon	Body	Rear Heated Seat Module																																V				V																						
K	2010	Yukon	Body	Rear HVAC/RSA																																																									
K	2010	Yukon	Body	Right Side Object Detection Module																																						V					V													
K	2010	Yukon	Body	Supplemental Inflatable Restraint																																																									
K	2010	Yukon	Body	Theft Deterrent Module																																																									
K	2010	Yukon Hybrid	Powertrain	Engine Control Module	V			V																																																						
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																									
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																									
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																									
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																						V																																			
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																									
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																									
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module		V																																																							
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module											V																																														
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																									
K	2010	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																									
K	2010	Yukon Hybrid	Body	Driver Door Switch																																																									
K	2010	Yukon Hybrid	Body	Heated Seat Module																																V				V																						
K	2010	Yukon Hybrid	Body	HVAC Control Module																											V	V																													
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																							V					V													
K	2010	Yukon Hybrid	Body	Lift Gate Module																																																									
K	2010	Yukon Hybrid	Body	Park Assist Module																																						V	V	V																	
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																																									
K	2010	Yukon Hybrid	Body	Passenger Presence System																																									V																
K	2010	Yukon Hybrid	Body	Radio																																																									
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																V				V																						
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																							V					V													
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																									
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																														

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																							
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																								
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module											V																																															
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed											V																																															
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed											V																																															
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																							
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed											V																																															
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed											V																																															
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed											V																																															
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed											V																																															
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																											
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW														V																																												
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																											
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																											
K	2010	Yukon XL	Body	Amplifier (Bose)																																																											
K	2010	Yukon XL	Body	Assist Step Controller																																																											
K	2010	Yukon XL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																											
K	2010	Yukon XL	Body	Digital Radio Receiver																																																											
K	2010	Yukon XL	Body	Driver Door Switch																																																											
K	2010	Yukon XL	Body	HVAC Control Module Auto																												V	V																														
K	2010	Yukon XL	Body	HVAC Control Module Manual																													V																														
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																											
K	2010	Yukon XL	Body	Left Side Object Detection Module																																								V					V													
K	2010	Yukon XL	Body	Lift Gate Module																																																											
K	2010	Yukon XL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																					
K	2010	Yukon XL	Body	Park Assist Module																																							V	V	V																		
K	2010	Yukon XL	Body	Passenger Door Switch																																																											
K	2010	Yukon XL	Body	Passenger Presence System																																										V																	
K	2010	Yukon XL	Body	Radio																																																										
K	2010	Yukon XL	Body	Rear Heated Seat Module																																	V				V																						
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																											
K	2010	Yukon XL	Body	Right Side Object Detection Module																																								V					V													
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
K	2010	Yukon XL	Body	Theft Deterrent Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
L	2004	ALL	Chassis	4WAL 3 Sensor																																																												
L	2004	ALL	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2004	ALL	Body	Instrument Panel Cluster																																																										
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
L	2005	ALL	Chassis	4WAL 3 Sensor																																																											
L	2005	ALL	Body	Body Control Module																																																										
L	2005	ALL	Body	Instrument Panel Cluster																																																											
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																											
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																											
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																											
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																											
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																											
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2010	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2010	Terrain	Body	Body Control Module																																																											
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2010	Terrain	Body	Passenger Presence Module																																																											
L	2010	Terrain	Body	Instrument Cluster																																																											
L	2010	Terrain	Body	Radio																																																											
L	2010	Terrain	Body	Multimedia Player Interface Module																																																											
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																																											
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2010	Terrain	Body	Liftgate Control Module																																																											
L	2010	Terrain	Body	Parking Assist Control Module																																																											
L	2010	Terrain	Body	Frontview Camera Module																																																											
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																																											
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																																											
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																											
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																											
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2011	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2011	Terrain	Body	Body Control Module																																																											
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2011	Terrain	Body	Passenger Presence Module																																																											
L	2011	Terrain	Body	Instrument Cluster																																																											
L	2011	Terrain	Body	Radio																																																											
L	2011	Terrain	Body	Multimedia Player Interface Module																																																											
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2011	Terrain	Body	Liftgate Control Module																																																												
L	2011	Terrain	Body	Parking Assist Control Module																																																												
L	2011	Terrain	Body	Frontview Camera Module																																																												
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																												
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2012	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2012	Terrain	Body	Body Control Module																																																												
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2012	Terrain	Body	Passenger Presence Module																																																												
L	2012	Terrain	Body	Instrument Cluster																																																												
L	2012	Terrain	Body	Radio																																																												
L	2012	Terrain	Body	Multimedia Player Interface Module																																																												
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2012	Terrain	Body	Liftgate Control Module																																																												
L	2012	Terrain	Body	Parking Assist Control Module																																																												
L	2012	Terrain	Body	Frontview Camera Module																																																												
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																																												
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2013	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2013	Terrain	Chassis	Power Steering Control Module																																																												
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																																												
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2013	Terrain	Body	Passenger Presence Module																																																												
L	2013	Terrain	Body	Instrument Cluster																																																												
L	2013	Terrain	Body	Radio																																																												
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2013	Terrain	Body	Liftgate Control Module																																																												
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																												
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																												
L	2013	Terrain	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2013	Terrain	Body	Frontview Camera Module																																																										
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2014	Terrain	Chassis	Power Steering Control Module																																																										
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																																										
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Terrain	Body	Passenger Presence Module																																																										
L	2014	Terrain	Body	Instrument Cluster																																																										
L	2014	Terrain	Body	Radio																																																										
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2014	Terrain	Body	Liftgate Control Module																																																										
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																										
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																										
L	2014	Terrain	Body	Parking Assist Control Module																																																										
L	2014	Terrain	Body	Frontview Camera Module																																																										
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2015	Terrain	Chassis	Power Steering Control Module																																																										
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																																										
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Terrain	Body	Passenger Presence Module																																																										
L	2015	Terrain	Body	Instrument Cluster																																																										
L	2015	Terrain	Body	Radio																																																										
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																																										
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2015	Terrain	Body	Liftgate Control Module																																																										
L	2015	Terrain	Body	Seat Memory Control Module																																																										
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																										
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																										
L	2015	Terrain	Body	Parking Assist Control Module																																																										
L	2015	Terrain	Body	Frontview Camera Module																																																										
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2016	Terrain	Chassis	Power Steering Control Module																																																										
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																																										
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Terrain	Body	Passenger Presence Module																																																										
L	2016	Terrain	Body	Instrument Cluster																																																										
L	2016	Terrain	Body	Radio																																																										
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																																										
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2016	Terrain	Body	Liftgate Control Module																																																										
L	2016	Terrain	Body	Seat Memory Control Module																																																										
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																										
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																										
L	2016	Terrain	Body	Parking Assist Control Module																																																										
L	2016	Terrain	Body	Frontview Camera Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
M	2004	ALL	Chassis	4WAL 3 Sensor																																																										
M	2004	ALL	Body	Body Control Module																																																										
M	2004	ALL	Body	Instrument Panel Cluster																																																										
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
M	2005	ALL	Chassis	4WAL 3 Sensor																																																										
M	2005	ALL	Body	Body Control Module																																																										
M	2005	ALL	Body	Instrument Panel Cluster																																																										
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
P	2007	ALL	Body	Theft Deterrent Module																																																										
R	2007	ALL	Powertrain	Engine Control Module	V			V																																																						
R	2007	ALL	Powertrain	Transmission Control Module		V																																																								
R	2007	ALL	Chassis	Electronic Brake Control Module													V																																													
R	2007	ALL	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																															
R	2007	ALL	Body	Digital Radio Receiver																																																										
R	2007	ALL	Body	Driver Door Switch																																																										
R	2007	ALL	Body	Head Up Display																																																										
R	2007	ALL	Body	Heated Seat Module																														V	V																											
R	2007	ALL	Body	HVAC Control Module Auto																												V	V																												
R	2007	ALL	Body	HVAC Control Module Manual																													V																												
R	2007	ALL	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2007	ALL	Body	Lift Gate Module																																																										
R	2007	ALL	Body	Park Assist Module																																							V	V	V																	
R	2007	ALL	Body	Passenger Door Switch																																																										
R	2007	ALL	Body	Passenger Presence System																																										V	V																
R	2007	ALL	Body	Radio																																																										
R	2007	ALL	Body	Rear HVAC/RSA																																																										
R	2007	ALL	Body	Rollover Sensor																																																										
R	2007	ALL	Body	Supplemental Inflatable Restraint																																										V									V							
R	2007	ALL	Body	Theft Deterrent Module																																																										
R	2008	ALL	Powertrain	Engine Control Module	V			V																																																							
R	2008	ALL	Powertrain	Transmission Control Module		V																																																									
R	2008	ALL	Chassis	Electronic Brake Control Module													V																																													
R	2008	ALL	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																																
R	2008	ALL	Body	Digital Radio Receiver																																																										
R	2008	ALL	Body	Driver Door Switch																																																										
R	2008	ALL	Body	Head Up Display																																																										
R	2008	ALL	Body	Heated Seat Module																														V	V																												
R	2008	ALL	Body	HVAC Control Module Auto																												V	V																													
R	2008	ALL	Body	HVAC Control Module Manual																													V																													
R	2008	ALL	Body	Instrument Panel Cluster																																																										
R	2008	ALL	Body	Lift Gate Module																																																										
R	2008	ALL	Body	Park Assist Module																																							V	V	V																	
R	2008	ALL	Body	Passenger Door Switch																																																										
R	2008	ALL	Body	Passenger Presence System																																										V	V																
R	2008	ALL	Body	Radio																																																										
R	2008	ALL	Body	Rear HVAC/RSA																																																										
R	2008	ALL	Body	Rollover Sensor																																																										
R	2008	ALL	Body	Supplemental Inflatable Restraint																																										V									V							
R	2008	ALL	Body	Theft Deterrent Module																																																										
R	2009	ALL	Powertrain	Engine Control Module				V						V																																																	
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2009	ALL	Powertrain	Transmission Control Module		V																																																									
R	2009	ALL	Chassis	Electronic Brake Control Module													V																																													
R	2009	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
R	2009	ALL	Body	Digital Radio Receiver																																																										
R	2009	ALL	Body	Driver Door Switch																																																										
R	2009	ALL	Body	Head Up Display																																																										
R	2009	ALL	Body	Heated Seat Module																														V	V																												
R	2009	ALL	Body	HVAC Control Module Auto																												V	V																													
R	2009	ALL	Body	HVAC Control Module Manual																													V																													
R	2009	ALL	Body	Instrument Panel Cluster																																																										
R	2009	ALL	Body	Lift Gate Module																																																										
R	2009	ALL	Body	Park Assist Module																																							V	V	V																	
R	2009	ALL	Body	Passenger Door Switch																																																										
R	2009	ALL	Body	Passenger Presence System																																										V																	
R	2009	ALL	Body	Radio																																																										
R	2009	ALL	Body	Rear HVAC/RSA																																																										
R	2009	ALL	Body	Rollover Sensor																																																										
R	2009	ALL	Body	Supplemental Inflatable Restraint																																										V									V							
R	2009	ALL	Body	Theft Deterrent Module																																																										
R	2010	ALL	Powertrain	Engine Control Module				V																																																							

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2010	ALL	Powertrain	Transmission Control Module		V																																																								
R	2010	ALL	Chassis	Electronic Brake Control Module													V																																												
R	2010	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
R	2010	ALL	Body	Digital Radio Receiver																																																										
R	2010	ALL	Body	Driver Door Switch																																																										
R	2010	ALL	Body	Head Up Display																																																										
R	2010	ALL	Body	Heated Seat Module																														V	V																												
R	2010	ALL	Body	HVAC Control Module Auto																												V	V																														
R	2010	ALL	Body	HVAC Control Module Manual																													V																															
R	2010	ALL	Body	Instrument Panel Cluster																																																										
R	2010	ALL	Body	Lift Gate Module																																																										
R	2010	ALL	Body	Park Assist Module																																							V	V	V																		
R	2010	ALL	Body	Passenger Door Switch																																																										
R	2010	ALL	Body	Passenger Presence System																																										V																
R	2010	ALL	Body	Radio																																																										
R	2010	ALL	Body	Rear HVAC/RSA																																																										
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2010	ALL	Body	Theft Deterrent Module																																																										
R	2011	ALL	Powertrain	Engine Control Module				V																																																							
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2011	ALL	Powertrain	Transmission Control Module		V																																																									
R	2011	ALL	Chassis	Electronic Brake Control Module													V																																													
R	2011	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
R	2011	ALL	Body	Digital Radio Receiver																																																										
R	2011	ALL	Body	Driver Door Switch																																																										
R	2011	ALL	Body	Head Up Display																																																										
R	2011	ALL	Body	Heated Seat Module																														V	V																												
R	2011	ALL	Body	HVAC Control Module Auto																												V	V																														
R	2011	ALL	Body	HVAC Control Module Manual																													V																															
R	2011	ALL	Body	Instrument Panel Cluster																																																										
R	2011	ALL	Body	Lift Gate Module																																																										
R	2011	ALL	Body	Park Assist Module																																							V	V	V																		
R	2011	ALL	Body	Passenger Door Switch																																																										
R	2011	ALL	Body	Passenger Presence System																																										V																
R	2011	ALL	Body	Radio																																																										
R	2011	ALL	Body	Rear HVAC/RSA																																																										
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2011	ALL	Body	Theft Deterrent Module																																																										
R	2012	ALL	Powertrain	Engine Control Module	V			V					V																																																	
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2012	ALL	Powertrain	Transmission Control Module		V																																																									
R	2012	ALL	Chassis	Electronic Brake Control Module													V																																													
R	2012	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
R	2012	ALL	Body	Digital Radio Receiver																																																										
R	2012	ALL	Body	Driver Door Switch																																																										
R	2012	ALL	Body	Head Up Display																																																										
R	2012	ALL	Body	Heated Seat Module																														V	V																												
R	2012	ALL	Body	HVAC Control Module Auto																												V	V																														
R	2012	ALL	Body	HVAC Control Module Manual																													V																															
R	2012	ALL	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2012	ALL	Body	Lift Gate Module																																																										
R	2012	ALL	Body	Park Assist Module																																							V	V	V																
R	2012	ALL	Body	Passenger Door Switch																																																									
R	2012	ALL	Body	Passenger Presence System																																									V																
R	2012	ALL	Body	Radio																																																									
R	2012	ALL	Body	Rear HVAC/RSA																																																									
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2012	ALL	Body	Theft Deterrent Module																																																									
R	2013	ALL	Powertrain	Engine Control Module	V			V					V																																																	
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2013	ALL	Powertrain	Transmission Control Module		V																																																								
R	2013	ALL	Chassis	Electronic Brake Control Module													V																																												
R	2013	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
R	2013	ALL	Body	Digital Radio Receiver																																																										
R	2013	ALL	Body	Driver Door Switch																																																										
R	2013	ALL	Body	Head Up Display																																																										
R	2013	ALL	Body	Heated Seat Module																														V	V																												
R	2013	ALL	Body	HVAC Control Module Auto																												V	V																														
R	2013	ALL	Body	HVAC Control Module Manual																													V																														
R	2013	ALL	Body	Instrument Panel Cluster																																																										
R	2013	ALL	Body	Left Side Object Detection Module																																																										
R	2013	ALL	Body	Lift Gate Module																																																										
R	2013	ALL	Body	Park Assist Module																																							V	V	V																		
R	2013	ALL	Body	Passenger Door Switch																																																										
R	2013	ALL	Body	Passenger Presence System																																									V																	
R	2013	ALL	Body	Radio																																																										
R	2013	ALL	Body	Rear HVAC/RSA																																																										
R	2013	ALL	Body	Right Side Object Detection Module																																																										
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2013	ALL	Body	Theft Deterrent Module																																																										
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2014	Acadia	Powertrain	Chassis Control Module																																																										
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
R	2014	Acadia	Chassis	Electronic Brake Control Module																																																										
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2014	Acadia	Body	Passenger Presence Module																																																										
R	2014	Acadia	Body	Instrument Cluster																																																										
R	2014	Acadia	Body	Head-Up Display Module																																																										
R	2014	Acadia	Body	Radio																																																										
R	2014	Acadia	Body	Rear Audio Control Module																																																										
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																										
R	2014	Acadia	Body	Personal Audio Link Control Module																																																										
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																										
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2014	Acadia	Body	Liftgate Control Module																																																										
R	2014	Acadia	Body	Seat Memory Control Module																																																											
R	2014	Acadia	Body	Front Seat Heating Control Module																																																											
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																											
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																											
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																											
R	2014	Acadia	Body	Parking Assist Control Module																																																											
R	2014	Acadia	Body	Frontview Camera Module																																																												
R	2014	Acadia	Body	Theft Deterrent Module																																																												
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
R	2015	Acadia	Chassis	Electronic Brake Control Module																																																												
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Acadia	Body	Passenger Presence Module																																																												
R	2015	Acadia	Body	Instrument Cluster																																																												
R	2015	Acadia	Body	Head-Up Display Module																																																												
R	2015	Acadia	Body	Radio																																																											
R	2015	Acadia	Body	Rear Audio Control Module																																																												
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																												
R	2015	Acadia	Body	Personal Audio Link Control Module																																																												
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																												
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																												
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																												
R	2015	Acadia	Body	Liftgate Control Module																																																												
R	2015	Acadia	Body	Seat Memory Control Module																																																												
R	2015	Acadia	Body	Front Seat Heating Control Module																																																												
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																												
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																												
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																												
R	2015	Acadia	Body	Parking Assist Control Module																																																												
R	2015	Acadia	Body	Frontview Camera Module																																																												
R	2015	Acadia	Body	Theft Deterrent Module																																																												
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
R	2016	Acadia	Chassis	Electronic Brake Control Module																																																												
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2016	Acadia	Body	Passenger Presence Module																																																												
R	2016	Acadia	Body	Instrument Cluster																																																												
R	2016	Acadia	Body	Head-Up Display Module																																																												
R	2016	Acadia	Body	Radio																																																											
R	2016	Acadia	Body	Rear Audio Control Module																																																												
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
R	2016	Acadia	Body	Personal Audio Link Control Module																																																										
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																										
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Acadia	Body	Liftgate Control Module																																																										
R	2016	Acadia	Body	Seat Memory Control Module																																																										
R	2016	Acadia	Body	Front Seat Heating Control Module																																																										
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																										
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																										
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																										
R	2016	Acadia	Body	Parking Assist Control Module																																																										
R	2016	Acadia	Body	Frontview Camera Module																																																										
R	2016	Acadia	Body	Theft Deterrent Module																																																										
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																										
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Sonoma	Body	Body Control Module																																																										
S	2004	Sonoma	Body	Instrument Panel Cluster																																																										
S	2004	Sonoma	Body	Base Radio																																																										
S	2004	Sonoma	Body	Uplevel Radio																																																										
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																										
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2004	Canyon	Chassis	ABS Without Traction Control																																																										
S	2004	Canyon	Chassis	ABS With Traction Control																																																										
S	2004	Canyon	Body	Body Control Module																																																										
S	2004	Canyon	Body	Instrument Panel Cluster																																																										
S	2004	Canyon	Body	OnStar																																																										
S	2004	Canyon	Body	Base Radio																																																										
S	2004	Canyon	Body	Uplevel Radio																																																										
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy	Body	Amplifier (Bose)																																																										
S	2004	Envoy	Body	Body Control Module																																																										
S	2004	Envoy	Body	Driver Door Module																																																										
S	2004	Envoy	Body	Driver Seat Module																																																										
S	2004	Envoy	Body	Heating and Air Conditioning Auto																																																										
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy	Body	Instrument Panel Cluster																																																										
S	2004	Envoy	Body	Lift Gate Module																																																										
S	2004	Envoy	Body	OnStar																																																										
S	2004	Envoy	Body	Passenger Door Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2004	Envoy	Body	Uplevel Radio																																																									
S	2004	Envoy	Body	Navigation Radio																																																									
S	2004	Envoy	Body	Rear Seat Audio																																																									
S	2004	Envoy	Body	Rear Seat Entertainment																																																									
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																																									
S	2004	Envoy	Body	Vehicle Theft Deterrent																																																									
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																									
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																									
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																									
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																									
S	2004	Envoy XL	Body	Amplifier (Bose)																																																									
S	2004	Envoy XL	Body	Body Control Module																																																									
S	2004	Envoy XL	Body	Driver Door Module																																																									
S	2004	Envoy XL	Body	Driver Seat Module																																																									
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																									
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																									
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																									
S	2004	Envoy XL	Body	Lift Gate Module																																																									
S	2004	Envoy XL	Body	OnStar																																																									
S	2004	Envoy XL	Body	Passenger Door Module																																																									
S	2004	Envoy XL	Body	Uplevel Radio																																																									
S	2004	Envoy XL	Body	Navigation Radio																																																									
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																									
S	2004	Envoy XL	Body	Rear HVAC Manual																																																									
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																									
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																									
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																									
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																									
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																									
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																									
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																									
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																									
S	2004	Envoy XUV	Body	Body Control Module																																																									
S	2004	Envoy XUV	Body	Driver Door Module																																																									
S	2004	Envoy XUV	Body	Driver Seat Module																																																									
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																									
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																									
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																									
S	2004	Envoy XUV	Body	Lift Gate Module																																																									
S	2004	Envoy XUV	Body	OnStar																																																									
S	2004	Envoy XUV	Body	Passenger Door Module																																																									
S	2004	Envoy XUV	Body	Uplevel Radio																																																									
S	2004	Envoy XUV	Body	Navigation Radio																																																									
S	2004	Envoy XUV	Body	Rear Seat Audio																																																									
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																										
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Jimmy	Body	Body Control Module																																																										
S	2004	Jimmy	Body	Heating and Air Conditioning																																																										
S	2004	Jimmy	Body	Instrument Panel Cluster																																																										
S	2004	Jimmy	Body	Memory Seat Module																																																										
S	2004	Jimmy	Body	Base Radio																																																										
S	2004	Jimmy	Body	Uplevel Radio																																																										
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2005	Canyon	Chassis	ABS Without Traction Control																																																										
S	2005	Canyon	Chassis	ABS With Traction Control																																																										
S	2005	Canyon	Body	Body Control Module																																																										
S	2005	Canyon	Body	Instrument Panel Cluster																																																										
S	2005	Canyon	Body	Base Radio																																																										
S	2005	Canyon	Body	Uplevel Radio																																																										
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																						
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy	Body	Body Control Module																																																										
S	2005	Envoy	Body	Disc Player and Video Display																																																										
S	2005	Envoy	Body	Driver Door Module																																																										
S	2005	Envoy	Body	Driver Seat Module																																																										
S	2005	Envoy	Body	Heating and Air Conditioning Auto																																																										
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy	Body	Instrument Panel Cluster																																																										
S	2005	Envoy	Body	Lift Gate Module																																																										
S	2005	Envoy	Body	Passenger Door Module																																																										
S	2005	Envoy	Body	Passenger Presence System																																																										
S	2005	Envoy	Body	Uplevel Radio																																																										
S	2005	Envoy	Body	Navigation Radio																																																										
S	2005	Envoy	Body	Rear Seat Audio																																																										
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																						

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																											
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																											
S	2005	Envoy XL	Body	Body Control Module																																																											
S	2005	Envoy XL	Body	Disc Player and Video Display																																																											
S	2005	Envoy XL	Body	Driver Door Module																																																											
S	2005	Envoy XL	Body	Driver Seat Module																																																											
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																											
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																											
S	2005	Envoy XL	Body	Instrument Panel Cluster																																																											
S	2005	Envoy XL	Body	Lift Gate Module																																																											
S	2005	Envoy XL	Body	Passenger Door Module																																																											
S	2005	Envoy XL	Body	Passenger Presence System																																																											
S	2005	Envoy XL	Body	Uplevel Radio																																																											
S	2005	Envoy XL	Body	Navigation Radio																																																											
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																											
S	2005	Envoy XL	Body	Rear HVAC Manual																																																											
S	2005	Envoy XL	Body	Rear Seat Audio																																																											
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																											
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																											
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																											
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																											
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																											
S	2005	Envoy XUV	Body	Body Control Module																																																											
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																											
S	2005	Envoy XUV	Body	Driver Door Module																																																											
S	2005	Envoy XUV	Body	Driver Seat Module																																																											
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																											
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																											
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																																											
S	2005	Envoy XUV	Body	Lift Gate Module																																																											
S	2005	Envoy XUV	Body	Passenger Door Module																																																											
S	2005	Envoy XUV	Body	Passenger Presence System																																																											
S	2005	Envoy XUV	Body	Uplevel Radio																																																											
S	2005	Envoy XUV	Body	Navigation Radio																																																											
S	2005	Envoy XUV	Body	Rear Seat Audio																																																											
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																											
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																											
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																											
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																											
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																											
S	2005	Jimmy	Body	Body Control Module																																																											
S	2005	Jimmy	Body	Heating and Air Conditioning																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2005	Jimmy	Body	Instrument Panel Cluster																																																											
S	2005	Jimmy	Body	Memory Seat Module																																																												
S	2005	Jimmy	Body	Base Radio																																																											
S	2005	Jimmy	Body	Uplevel Radio																																																											
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																											
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																											
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																											
S	2005	Sonoma	Body	Body Control Module																																																											
S	2005	Sonoma	Body	Instrument Panel Cluster																																																											
S	2005	Sonoma	Body	Base Radio																																																											
S	2005	Sonoma	Body	Uplevel Radio																																																											
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																											
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2006	Canyon	Chassis	ABS Without Traction Control																																																											
S	2006	Canyon	Chassis	ABS With Traction Control																																																											
S	2006	Canyon	Body	Body Control Module																																																											
S	2006	Canyon	Body	Instrument Panel Cluster																																																											
S	2006	Canyon	Body	Passenger Presence System																																																											
S	2006	Canyon	Body	Base Radio																																																											
S	2006	Canyon	Body	Uplevel Radio																																																											
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																																											
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																							
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2006	Envoy	Chassis	ABS/TCS/VSES														V																																												
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																											
S	2006	Envoy	Body	Body Control Module																																																											
S	2006	Envoy	Body	Disc Player and Video Display																																																											
S	2006	Envoy	Body	Driver Door Module																																																											
S	2006	Envoy	Body	Driver Seat Module																																																											
S	2006	Envoy	Body	Heating and Air Conditioning Auto																																																											
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																																											
S	2006	Envoy	Body	Instrument Panel Cluster																																																											
S	2006	Envoy	Body	Lift Gate Module																																																											
S	2006	Envoy	Body	Passenger Door Module																																																											
S	2006	Envoy	Body	Passenger Presence System																																																											
S	2006	Envoy	Body	Uplevel Radio																																																											
S	2006	Envoy	Body	Navigation Radio																																																											
S	2006	Envoy	Body	Rear Seat Audio																																																											
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																																											
S	2006	Envoy	Body	Vehicle Theft Deterrent																																																											
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2006	Envoy XL	Chassis	ABS/TCS/VSES														V																																												
S	2006	Envoy XL	Body	Body Control Module																																																											
S	2006	Envoy XL	Body	Disc Player and Video Display																																																											
S	2006	Envoy XL	Body	Driver Door Module																																																											
S	2006	Envoy XL	Body	Driver Seat Module																																																											
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																											
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																											
S	2006	Envoy XL	Body	Instrument Panel Cluster																																																											
S	2006	Envoy XL	Body	Lift Gate Module																																																											
S	2006	Envoy XL	Body	Passenger Door Module																																																											
S	2006	Envoy XL	Body	Passenger Presence System																																																											
S	2006	Envoy XL	Body	Uplevel Radio																																																											
S	2006	Envoy XL	Body	Navigation Radio																																																											
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																											
S	2006	Envoy XL	Body	Rear HVAC Manual																																																											
S	2006	Envoy XL	Body	Rear Seat Audio																																																											
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																											
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																											
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																											
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module									V	V																																																	
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module									V	V																																																	
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																											
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																											
S	2007	Canyon	Body	Body Control Module																																																											
S	2007	Canyon	Body	Digital Radio Receiver																																																											
S	2007	Canyon	Body	Generator Battery Control Module																																																											
S	2007	Canyon	Body	Instrument Panel Cluster																																																											
S	2007	Canyon	Body	Passenger Presence System																																																											
S	2007	Canyon	Body	Base Radio																																																											
S	2007	Canyon	Body	Uplevel Radio																																																											
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module									V	V																																																	
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module									V	V																																																	
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																											
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																							
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2007	Envoy	Chassis	Electronic Brake Control Module														V																																												
S	2007	Envoy	Body	Body Control Module																																																											
S	2007	Envoy	Body	Digital Radio Receiver																																																											
S	2007	Envoy	Body	Disc Player and Video Display																																																											
S	2007	Envoy	Body	Driver Door Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2007	Envoy	Body	Driver Seat Module																																																											
S	2007	Envoy	Body	Generator Battery Control Module																																																												
S	2007	Envoy	Body	HVAC Control Module Auto																																																												
S	2007	Envoy	Body	HVAC Control Module Manual																																																												
S	2007	Envoy	Body	Instrument Panel Cluster																																																												
S	2007	Envoy	Body	Lift Gate Module																																																												
S	2007	Envoy	Body	Passenger Door Module																																																												
S	2007	Envoy	Body	Passenger Presence System																																																												
S	2007	Envoy	Body	Uplevel Radio																																																												
S	2007	Envoy	Body	Navigation Radio																																																												
S	2007	Envoy	Body	Rear Seat Audio																																																												
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2007	Envoy	Body	Theft Deterrent Module																																																												
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																																												
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																	
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module				V					V	V																																																	
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2008	Canyon	Body	Body Control Module																																																												
S	2008	Canyon	Body	Digital Radio Receiver																																																												
S	2008	Canyon	Body	Generator Battery Control Module																																																												
S	2008	Canyon	Body	Instrument Panel Cluster																																																												
S	2008	Canyon	Body	Passenger Presence System																																																												
S	2008	Canyon	Body	Base Radio																																																												
S	2008	Canyon	Body	Uplevel Radio																																																												
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																																												
S	2008	Canyon	Body	Theft Deterrent Module																																																												
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																																												
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module				V					V	V																																																		
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																								
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																								
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2008	Envoy	Chassis	Electronic Brake Control Module														V																																													
S	2008	Envoy	Body	Body Control Module																																																												
S	2008	Envoy	Body	Digital Radio Receiver																																																												
S	2008	Envoy	Body	Disc Player and Video Display																																																												
S	2008	Envoy	Body	Driver Door Module																																																												
S	2008	Envoy	Body	Driver Seat Module																																																												
S	2008	Envoy	Body	Generator Battery Control Module																																																												
S	2008	Envoy	Body	HVAC Control Module Auto																																																												
S	2008	Envoy	Body	HVAC Control Module Manual																																																												
S	2008	Envoy	Body	Instrument Panel Cluster																																																												
S	2008	Envoy	Body	Lift Gate Module																																																												
S	2008	Envoy	Body	Passenger Door Module																																																												
S	2008	Envoy	Body	Passenger Presence System																																																												
S	2008	Envoy	Body	Uplevel Radio																																																												
S	2008	Envoy	Body	Navigation Radio																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2008	Envoy	Body	Rear Seat Audio																																																											
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																																											
S	2008	Envoy	Body	Theft Deterrent Module																																																											
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																																											
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																	
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																	
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module	V			V																																																							
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																											
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																											
S	2009	Canyon	Chassis	Electronic Brake Control Module																																																											
S	2009	Canyon	Body	Body Control Module																																																											
S	2009	Canyon	Body	Digital Radio Receiver																																																											
S	2009	Canyon	Body	Generator Battery Control Module																																																											
S	2009	Canyon	Body	Instrument Panel Cluster																																																											
S	2009	Canyon	Body	Passenger Presence System																																																											
S	2009	Canyon	Body	Base Radio																																																											
S	2009	Canyon	Body	Uplevel Radio																																																											
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2009	Canyon	Body	Theft Deterrent Module																																																											
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module				V						V																																																	
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																											
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																							
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																											
S	2009	Envoy	Chassis	Electronic Brake Control Module														V																																													
S	2009	Envoy	Body	Body Control Module																																																											
S	2009	Envoy	Body	Digital Radio Receiver																																																											
S	2009	Envoy	Body	Disc Player and Video Display																																																											
S	2009	Envoy	Body	Driver Door Module																																																											
S	2009	Envoy	Body	Driver Seat Module																																																											
S	2009	Envoy	Body	Generator Battery Control Module																																																											
S	2009	Envoy	Body	HVAC Control Module Auto																																																											
S	2009	Envoy	Body	HVAC Control Module Manual																																																											
S	2009	Envoy	Body	Instrument Panel Cluster																																																											
S	2009	Envoy	Body	Lift Gate Module																																																											
S	2009	Envoy	Body	Passenger Door Module																																																											
S	2009	Envoy	Body	Passenger Presence System																																																											
S	2009	Envoy	Body	Uplevel Radio																																																											
S	2009	Envoy	Body	Navigation Radio																																																											
S	2009	Envoy	Body	Rear Seat Audio																																																											
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																																											
S	2009	Envoy	Body	Theft Deterrent Module																																																											
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																	

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																	
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V			V																																																							
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
S	2010	ALL	Chassis	Electronic Brake Control Module																																																												
S	2010	ALL	Body	Body Control Module																																																											
S	2010	ALL	Body	Digital Radio Receiver																																																											
S	2010	ALL	Body	Generator Battery Control Module																																																											
S	2010	ALL	Body	Instument Panel Cluster																																																											
S	2010	ALL	Body	Passenger Presence System																																																											
S	2010	ALL	Body	Personal Audio Link Module																																																											
S	2010	ALL	Body	Base Radio																																																											
S	2010	ALL	Body	Uplevel Radio																																																											
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
S	2010	ALL	Body	Theft Deterrent Module																																																											
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																											
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																											
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																											
T	2004	Sonoma	Body	Body Control Module																																																											
T	2004	Sonoma	Body	Instrument Panel Cluster																																																											
T	2004	Sonoma	Body	Base Radio																																																											
T	2004	Sonoma	Body	Uplevel Radio																																																											
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																											
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
T	2004	Canyon	Chassis	ABS Without Traction Control																																																											
T	2004	Canyon	Chassis	ABS With Traction Control																																																											
T	2004	Canyon	Body	Body Control Module																																																											
T	2004	Canyon	Body	Instrument Panel Cluster																																																											
T	2004	Canyon	Body	OnStar																																																											
T	2004	Canyon	Body	Base Radio																																																											
T	2004	Canyon	Body	Uplevel Radio																																																											
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																																											
T	2004	Canyon	Body	Instrument Panel Cluster																																																											
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active											V																																																
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable											V																																																
T	2004	Envoy	Chassis	ABS Without Traction Control																																																											
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																											
T	2004	Envoy	Body	Amplifier (Bose)																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2004	Envoy	Body	Body Control Module																																																										
T	2004	Envoy	Body	Driver Door Module																																																										
T	2004	Envoy	Body	Driver Seat Module																																																										
T	2004	Envoy	Body	Heating and Air Conditioning Auto																																																										
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																																										
T	2004	Envoy	Body	Instrument Panel Cluster																																																										
T	2004	Envoy	Body	Lift Gate Module																																																										
T	2004	Envoy	Body	OnStar																																																										
T	2004	Envoy	Body	Passenger Door Module																																																										
T	2004	Envoy	Body	Uplevel Radio																																																										
T	2004	Envoy	Body	Navigation Radio																																																										
T	2004	Envoy	Body	Rear Seat Audio																																																										
T	2004	Envoy	Body	Rear Seat Entertainment																																																										
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display											V																																															
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display											V																																															
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy XL	Body	Amplifier (Bose)																																																										
T	2004	Envoy XL	Body	Body Control Module																																																										
T	2004	Envoy XL	Body	Driver Door Module																																																										
T	2004	Envoy XL	Body	Driver Seat Module																																																										
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2004	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2004	Envoy XL	Body	Lift Gate Module																																																										
T	2004	Envoy XL	Body	OnStar																																																										
T	2004	Envoy XL	Body	Passenger Door Module																																																										
T	2004	Envoy XL	Body	Uplevel Radio																																																										
T	2004	Envoy XL	Body	Navigation Radio																																																										
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2004	Envoy XL	Body	Rear HVAC Manual																																																										
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																										
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display											V																																															
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display											V																																															
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2004	Envoy XUV	Body	Body Control Module																																																											
T	2004	Envoy XUV	Body	Driver Door Module																																																												
T	2004	Envoy XUV	Body	Driver Seat Module																																																												
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																												
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																												
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																																												
T	2004	Envoy XUV	Body	Lift Gate Module																																																												
T	2004	Envoy XUV	Body	OnStar																																																												
T	2004	Envoy XUV	Body	Passenger Door Module																																																												
T	2004	Envoy XUV	Body	Uplevel Radio																																																												
T	2004	Envoy XUV	Body	Navigation Radio																																																												
T	2004	Envoy XUV	Body	Rear Seat Audio																																																												
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																												
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																												
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																												
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																												
T	2004	Jimmy	Body	Body Control Module																																																												
T	2004	Jimmy	Body	Heating and Air Conditioning																																																												
T	2004	Jimmy	Body	Instrument Panel Cluster																																																												
T	2004	Jimmy	Body	Memory Seat Module																																																												
T	2004	Jimmy	Body	Base Radio																																																												
T	2004	Jimmy	Body	Uplevel Radio																																																												
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																												
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2005	Canyon	Chassis	ABS Without Traction Control																																																												
T	2005	Canyon	Chassis	ABS With Traction Control																																																												
T	2005	Canyon	Body	Body Control Module																																																												
T	2005	Canyon	Body	Instrument Panel Cluster																																																												
T	2005	Canyon	Body	Base Radio																																																												
T	2005	Canyon	Body	Uplevel Radio																																																												
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active											V																																																
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																											
T	2005	Envoy	Chassis	ABS Without Traction Control																																																												
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Envoy	Body	Body Control Module																																																												
T	2005	Envoy	Body	Disc Player and Video Display																																																												
T	2005	Envoy	Body	Driver Door Module																																																												
T	2005	Envoy	Body	Driver Seat Module																																																												
T	2005	Envoy	Body	Heating and Air Conditioning Auto																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																																									
T	2005	Envoy	Body	Instrument Panel Cluster																																																										
T	2005	Envoy	Body	Lift Gate Module																																																										
T	2005	Envoy	Body	Passenger Door Module																																																										
T	2005	Envoy	Body	Passenger Presence System																																																										
T	2005	Envoy	Body	Uplevel Radio																																																										
T	2005	Envoy	Body	Navigation Radio																																																										
T	2005	Envoy	Body	Rear Seat Audio																																																										
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2005	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display											V																																														
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																						
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display											V																																														
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy XL	Body	Body Control Module																																																										
T	2005	Envoy XL	Body	Disc Player and Video Display																																																										
T	2005	Envoy XL	Body	Driver Door Module																																																										
T	2005	Envoy XL	Body	Driver Seat Module																																																										
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2005	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2005	Envoy XL	Body	Lift Gate Module																																																										
T	2005	Envoy XL	Body	Passenger Door Module																																																										
T	2005	Envoy XL	Body	Passenger Presence System																																																										
T	2005	Envoy XL	Body	Uplevel Radio																																																										
T	2005	Envoy XL	Body	Navigation Radio																																																										
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2005	Envoy XL	Body	Rear HVAC Manual																																																										
T	2005	Envoy XL	Body	Rear Seat Audio																																																										
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																										
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display											V																																														
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																						
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display											V																																														
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy XUV	Body	Body Control Module																																																										
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																										
T	2005	Envoy XUV	Body	Driver Door Module																																																										
T	2005	Envoy XUV	Body	Driver Seat Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																											
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																											
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																																											
T	2005	Envoy XUV	Body	Lift Gate Module																																																											
T	2005	Envoy XUV	Body	Passenger Door Module																																																											
T	2005	Envoy XUV	Body	Passenger Presence System																																																											
T	2005	Envoy XUV	Body	Uplevel Radio																																																											
T	2005	Envoy XUV	Body	Navigation Radio																																																											
T	2005	Envoy XUV	Body	Rear Seat Audio																																																											
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																											
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																											
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																											
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																											
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																											
T	2005	Jimmy	Body	Body Control Module																																																											
T	2005	Jimmy	Body	Heating and Air Conditioning																																																											
T	2005	Jimmy	Body	Instrument Panel Cluster																																																											
T	2005	Jimmy	Body	Memory Seat Module																																																											
T	2005	Jimmy	Body	Base Radio																																																											
T	2005	Jimmy	Body	Uplevel Radio																																																											
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																											
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																											
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																											
T	2005	Sonoma	Body	Body Control Module																																																											
T	2005	Sonoma	Body	Instrument Panel Cluster																																																											
T	2005	Sonoma	Body	Base Radio																																																											
T	2005	Sonoma	Body	Uplevel Radio																																																											
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																											
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
T	2006	Canyon	Chassis	ABS Without Traction Control																																																											
T	2006	Canyon	Chassis	ABS With Traction Control																																																											
T	2006	Canyon	Body	Body Control Module																																																											
T	2006	Canyon	Body	Instrument Panel Cluster																																																											
T	2006	Canyon	Body	Passenger Presence System																																																											
T	2006	Canyon	Body	Base Radio																																																											
T	2006	Canyon	Body	Uplevel Radio																																																											
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																																											
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																																											
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display											V																																																
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display											V																																																
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																								
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2006	Envoy	Chassis	ABS/TCS/VSES														V																																													
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																												
T	2006	Envoy	Body	Body Control Module																																																												
T	2006	Envoy	Body	Disc Player and Video Display																																																												
T	2006	Envoy	Body	Driver Door Module																																																												
T	2006	Envoy	Body	Driver Seat Module																																																												
T	2006	Envoy	Body	Heating and Air Conditioning Auto																																																												
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																																												
T	2006	Envoy	Body	Instrument Panel Cluster																																																												
T	2006	Envoy	Body	Lift Gate Module																																																												
T	2006	Envoy	Body	Passenger Door Module																																																												
T	2006	Envoy	Body	Passenger Presence System																																																												
T	2006	Envoy	Body	Uplevel Radio																																																												
T	2006	Envoy	Body	Navigation Radio																																																												
T	2006	Envoy	Body	Rear Seat Audio																																																												
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2006	Envoy	Body	Vehicle Theft Deterrent																																																												
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																																												
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display											V																																																	
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																								
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display											V																																																	
T	2006	Envoy XL	Chassis	ABS/TCS/VSES														V																																													
T	2006	Envoy XL	Body	Body Control Module																																																												
T	2006	Envoy XL	Body	Disc Player and Video Display																																																												
T	2006	Envoy XL	Body	Driver Door Module																																																												
T	2006	Envoy XL	Body	Driver Seat Module																																																												
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
T	2006	Envoy XL	Body	Instrument Panel Cluster																																																												
T	2006	Envoy XL	Body	Lift Gate Module																																																												
T	2006	Envoy XL	Body	Passenger Door Module																																																												
T	2006	Envoy XL	Body	Passenger Presence System																																																												
T	2006	Envoy XL	Body	Uplevel Radio																																																												
T	2006	Envoy XL	Body	Navigation Radio																																																												
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
T	2006	Envoy XL	Body	Rear HVAC Manual																																																												
T	2006	Envoy XL	Body	Rear Seat Audio																																																												
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																												
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																												
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module									V	V																																																		
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module									V	V																																																		

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																												
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																												
T	2007	Canyon	Body	Body Control Module																																																												
T	2007	Canyon	Body	Digital Radio Receiver																																																												
T	2007	Canyon	Body	Generator Battery Control Module																																																												
T	2007	Canyon	Body	Instrument Panel Cluster																																																												
T	2007	Canyon	Body	Passenger Presence System																																																												
T	2007	Canyon	Body	Base Radio																																																												
T	2007	Canyon	Body	Uplevel Radio																																																												
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module									V	V																																																		
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module											V																																																
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module									V	V																																																		
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module											V																																																
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																								
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module											V																																																
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																								
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module											V																																																
T	2007	Envoy	Chassis	Electronic Brake Control Module														V																																													
T	2007	Envoy	Body	Body Control Module																																																												
T	2007	Envoy	Body	Digital Radio Receiver																																																												
T	2007	Envoy	Body	Disc Player and Video Display																																																												
T	2007	Envoy	Body	Driver Door Module																																																												
T	2007	Envoy	Body	Driver Seat Module																																																												
T	2007	Envoy	Body	Generator Battery Control Module																																																												
T	2007	Envoy	Body	HVAC Control Module Auto																																																												
T	2007	Envoy	Body	HVAC Control Module Manual																																																												
T	2007	Envoy	Body	Instrument Panel Cluster																																																												
T	2007	Envoy	Body	Lift Gate Module																																																												
T	2007	Envoy	Body	Passenger Door Module																																																												
T	2007	Envoy	Body	Passenger Presence System																																																												
T	2007	Envoy	Body	Uplevel Radio																																																												
T	2007	Envoy	Body	Navigation Radio																																																												
T	2007	Envoy	Body	Rear Seat Audio																																																												
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2007	Envoy	Body	Theft Deterrent Module																																																												
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																																												
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																		
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module				V					V	V																																																		
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2008	Canyon	Body	Body Control Module																																																										
T	2008	Canyon	Body	Digital Radio Receiver																																																											
T	2008	Canyon	Body	Generator Battery Control Module																																																											
T	2008	Canyon	Body	Instrument Panel Cluster																																																											
T	2008	Canyon	Body	Passenger Presence System																																																											
T	2008	Canyon	Body	Base Radio																																																											
T	2008	Canyon	Body	Uplevel Radio																																																											
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																																											
T	2008	Canyon	Body	Theft Deterrent Module																																																											
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																																											
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module				V					V	V																																																	
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module											V																																																
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module											V																																																
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																							
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2008	Envoy	Chassis	Electronic Brake Control Module														V																																													
T	2008	Envoy	Body	Body Control Module																																																											
T	2008	Envoy	Body	Digital Radio Receiver																																																											
T	2008	Envoy	Body	Disc Player and Video Display																																																											
T	2008	Envoy	Body	Driver Door Module																																																											
T	2008	Envoy	Body	Driver Seat Module																																																											
T	2008	Envoy	Body	Generator Battery Control Module																																																											
T	2008	Envoy	Body	HVAC Control Module Auto																																																											
T	2008	Envoy	Body	HVAC Control Module Manual																																																											
T	2008	Envoy	Body	Instrument Panel Cluster																																																											
T	2008	Envoy	Body	Lift Gate Module																																																											
T	2008	Envoy	Body	Passenger Door Module																																																											
T	2008	Envoy	Body	Passenger Presence System																																																											
T	2008	Envoy	Body	Uplevel Radio																																																											
T	2008	Envoy	Body	Navigation Radio																																																											
T	2008	Envoy	Body	Rear Seat Audio																																																											
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																																											
T	2008	Envoy	Body	Theft Deterrent Module																																																											
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																																											
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																	
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																	
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module	V			V																																																							
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																											
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																											
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																											
T	2009	Canyon	Chassis	Electronic Brake Control Module																																																											
T	2009	Canyon	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2009	Canyon	Body	Digital Radio Receiver																																																											
T	2009	Canyon	Body	Generator Battery Control Module																																																											
T	2009	Canyon	Body	Instrument Panel Cluster																																																											
T	2009	Canyon	Body	Passenger Presence System																																																											
T	2009	Canyon	Body	Base Radio																																																											
T	2009	Canyon	Body	Uplevel Radio																																																											
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																																											
T	2009	Canyon	Body	Theft Deterrent Module																																																											
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module				V						V																																																	
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module											V																																																
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module				V																																																							
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module											V																																																
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module				V																																																							
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
T	2009	Envoy	Chassis	Electronic Brake Control Module														V																																													
T	2009	Envoy	Body	Body Control Module																																																											
T	2009	Envoy	Body	Digital Radio Receiver																																																											
T	2009	Envoy	Body	Disc Player and Video Display																																																											
T	2009	Envoy	Body	Driver Door Module																																																											
T	2009	Envoy	Body	Driver Seat Module																																																											
T	2009	Envoy	Body	Generator Battery Control Module																																																											
T	2009	Envoy	Body	HVAC Control Module Auto																																																											
T	2009	Envoy	Body	HVAC Control Module Manual																																																											
T	2009	Envoy	Body	Instrument Panel Cluster																																																											
T	2009	Envoy	Body	Lift Gate Module																																																											
T	2009	Envoy	Body	Passenger Door Module																																																											
T	2009	Envoy	Body	Passenger Presence System																																																											
T	2009	Envoy	Body	Uplevel Radio																																																											
T	2009	Envoy	Body	Navigation Radio																																																											
T	2009	Envoy	Body	Rear Seat Audio																																																											
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																																											
T	2009	Envoy	Body	Theft Deterrent Module																																																											
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																	
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																	
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V			V																																																							
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
T	2010	ALL	Chassis	Electronic Brake Control Module																																																											
T	2010	ALL	Body	Body Control Module																																																											
T	2010	ALL	Body	Digital Radio Receiver																																																											
T	2010	ALL	Body	Generator Battery Control Module																																																											
T	2010	ALL	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
T	2010	ALL	Body	Passenger Presence System																																																										
T	2010	ALL	Body	Personal Audio Link Module																																																										
T	2010	ALL	Body	Base Radio																																																										
T	2010	ALL	Body	Uplevel Radio																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Theft Deterrent Module																																																										
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																										
V	2007	ALL	Powertrain	Engine Control Module	V			V																																																						
V	2007	ALL	Powertrain	Rear Drive System																																																										
V	2007	ALL	Powertrain	Transmission Control Module		V																																																								
V	2007	ALL	Chassis	Electronic Brake Control Module													V																																												
V	2007	ALL	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																															
V	2007	ALL	Body	Digital Radio Receiver																																																										
V	2007	ALL	Body	Driver Door Switch																																																										
V	2007	ALL	Body	Head Up Display																																																										
V	2007	ALL	Body	Heated Seat Module																														V	V																												
V	2007	ALL	Body	HVAC Control Module Auto																												V	V																													
V	2007	ALL	Body	HVAC Control Module Manual																													V																														
V	2007	ALL	Body	Instrument Panel Cluster																																																										
V	2007	ALL	Body	Lift Gate Module																																																										
V	2007	ALL	Body	Park Assist Module																																							V	V	V																	
V	2007	ALL	Body	Passenger Door Switch																																																										
V	2007	ALL	Body	Passenger Presence System																																										V	V															
V	2007	ALL	Body	Radio																																																										
V	2007	ALL	Body	Rear HVAC/RSA																																																										
V	2007	ALL	Body	Rollover Sensor																																																										
V	2007	ALL	Body	Supplemental Inflatable Restraint																																										V									V						
V	2007	ALL	Body	Theft Deterrent Module																																																										
V	2008	ALL	Powertrain	Engine Control Module	V			V																																																						
V	2008	ALL	Powertrain	Rear Drive System																																																										
V	2008	ALL	Powertrain	Transmission Control Module		V																																																								
V	2008	ALL	Chassis	Electronic Brake Control Module													V																																												
V	2008	ALL	Body	Body Control Module															V	V	V	V	V	V	V	V	V	V			V																															
V	2008	ALL	Body	Digital Radio Receiver																																																										
V	2008	ALL	Body	Driver Door Switch																																																										
V	2008	ALL	Body	Head Up Display																																																										
V	2008	ALL	Body	Heated Seat Module																														V	V																												
V	2008	ALL	Body	HVAC Control Module Auto																												V	V																													
V	2008	ALL	Body	HVAC Control Module Manual																													V																														
V	2008	ALL	Body	Instrument Panel Cluster																																																										
V	2008	ALL	Body	Lift Gate Module																																																										
V	2008	ALL	Body	Park Assist Module																																							V	V	V																	
V	2008	ALL	Body	Passenger Door Switch																																																										
V	2008	ALL	Body	Passenger Presence System																																										V	V															
V	2008	ALL	Body	Radio																																																										
V	2008	ALL	Body	Rear HVAC/RSA																																																										
V	2008	ALL	Body	Rollover Sensor																																																										
V	2008	ALL	Body	Supplemental Inflatable Restraint																																										V									V						
V	2008	ALL	Body	Theft Deterrent Module																																																										
V	2009	ALL	Powertrain	Engine Control Module				V						V																																																
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
V	2009	ALL	Powertrain	Rear Drive System																																																										
V	2009	ALL	Powertrain	Transmission Control Module		V																																																								
V	2009	ALL	Chassis	Electronic Brake Control Module													V																																												
V	2009	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
V	2009	ALL	Body	Digital Radio Receiver																																																										
V	2009	ALL	Body	Driver Door Switch																																																										
V	2009	ALL	Body	Head Up Display																																																										
V	2009	ALL	Body	Heated Seat Module																														V	V																												
V	2009	ALL	Body	HVAC Control Module Auto																												V	V																														
V	2009	ALL	Body	HVAC Control Module Manual																													V																														
V	2009	ALL	Body	Instrument Panel Cluster																																																										
V	2009	ALL	Body	Lift Gate Module																																																										
V	2009	ALL	Body	Park Assist Module																																							V	V	V																	
V	2009	ALL	Body	Passenger Door Switch																																																										
V	2009	ALL	Body	Passenger Presence System																																										V																
V	2009	ALL	Body	Radio																																																										
V	2009	ALL	Body	Rear HVAC/RSA																																																										
V	2009	ALL	Body	Rollover Sensor																																																										
V	2009	ALL	Body	Supplemental Inflatable Restraint																																										V									V							
V	2009	ALL	Body	Theft Deterrent Module																																																										
V	2010	ALL	Powertrain	Engine Control Module				V																																																							
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2010	ALL	Powertrain	Rear Drive System																																																											
V	2010	ALL	Powertrain	Transmission Control Module		V																																																									
V	2010	ALL	Chassis	Electronic Brake Control Module													V																																													
V	2010	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
V	2010	ALL	Body	Digital Radio Receiver																																																										
V	2010	ALL	Body	Driver Door Switch																																																										
V	2010	ALL	Body	Head Up Display																																																										
V	2010	ALL	Body	Heated Seat Module																														V	V																												
V	2010	ALL	Body	HVAC Control Module Auto																												V	V																														
V	2010	ALL	Body	HVAC Control Module Manual																													V																														
V	2010	ALL	Body	Instrument Panel Cluster																																																										
V	2010	ALL	Body	Lift Gate Module																																																										
V	2010	ALL	Body	Park Assist Module																																							V	V	V																	
V	2010	ALL	Body	Passenger Door Switch																																																										
V	2010	ALL	Body	Passenger Presence System																																										V																
V	2010	ALL	Body	Radio																																																										
V	2010	ALL	Body	Rear HVAC/RSA																																																										
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2010	ALL	Body	Theft Deterrent Module																																																										
V	2011	ALL	Powertrain	Engine Control Module				V																																																							
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2011	ALL	Powertrain	Rear Drive System																																																											
V	2011	ALL	Powertrain	Transmission Control Module		V																																																									
V	2011	ALL	Chassis	Electronic Brake Control Module													V																																													
V	2011	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
V	2011	ALL	Body	Digital Radio Receiver																																																										
V	2011	ALL	Body	Driver Door Switch																																																										
V	2011	ALL	Body	Head Up Display																																																										
V	2011	ALL	Body	Heated Seat Module																														V	V																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
V	2011	ALL	Body	HVAC Control Module Auto																												V	V																												
V	2011	ALL	Body	HVAC Control Module Manual																													V																													
V	2011	ALL	Body	Instrument Panel Cluster																																																										
V	2011	ALL	Body	Lift Gate Module																																																										
V	2011	ALL	Body	Park Assist Module																																							V	V	V																	
V	2011	ALL	Body	Passenger Door Switch																																																									
V	2011	ALL	Body	Passenger Presence System																																										V																
V	2011	ALL	Body	Radio																																																									
V	2011	ALL	Body	Rear HVAC/RSA																																																									
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2011	ALL	Body	Theft Deterrent Module																																																										
V	2012	ALL	Powertrain	Engine Control Module	V			V					V																																																	
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2012	ALL	Powertrain	Rear Drive System																																																										
V	2012	ALL	Powertrain	Transmission Control Module		V																																																								
V	2012	ALL	Chassis	Electronic Brake Control Module													V																																												
V	2012	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
V	2012	ALL	Body	Digital Radio Receiver																																																										
V	2012	ALL	Body	Driver Door Switch																																																										
V	2012	ALL	Body	Head Up Display																																																										
V	2012	ALL	Body	Heated Seat Module																															V	V																											
V	2012	ALL	Body	HVAC Control Module Auto																												V	V																														
V	2012	ALL	Body	HVAC Control Module Manual																													V																														
V	2012	ALL	Body	Instrument Panel Cluster																																																										
V	2012	ALL	Body	Lift Gate Module																																																										
V	2012	ALL	Body	Park Assist Module																																							V	V	V																	
V	2012	ALL	Body	Passenger Door Switch																																																										
V	2012	ALL	Body	Passenger Presence System																																										V																
V	2012	ALL	Body	Radio																																																										
V	2012	ALL	Body	Rear HVAC/RSA																																																										
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2012	ALL	Body	Theft Deterrent Module																																																										
V	2013	ALL	Powertrain	Engine Control Module	V			V					V																																																	
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2013	ALL	Powertrain	Rear Drive System																																																										
V	2013	ALL	Powertrain	Transmission Control Module		V																																																								
V	2013	ALL	Chassis	Electronic Brake Control Module													V																																												
V	2013	ALL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
V	2013	ALL	Body	Digital Radio Receiver																																																										
V	2013	ALL	Body	Driver Door Switch																																																										
V	2013	ALL	Body	Head Up Display																																																										
V	2013	ALL	Body	Heated Seat Module																															V	V																											
V	2013	ALL	Body	HVAC Control Module Auto																												V	V																														
V	2013	ALL	Body	HVAC Control Module Manual																													V																														
V	2013	ALL	Body	Instrument Panel Cluster																																																										
V	2013	ALL	Body	Left Side Object Detection Module																																																										
V	2013	ALL	Body	Lift Gate Module																																																										
V	2013	ALL	Body	Park Assist Module																																							V	V	V																	
V	2013	ALL	Body	Passenger Door Switch																																																										
V	2013	ALL	Body	Passenger Presence System																																										V																
V	2013	ALL	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
V	2013	ALL	Body	Rear HVAC/RSA																																																										
V	2013	ALL	Body	Right Side Object Detection Module																																																											
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2013	ALL	Body	Theft Deterrent Module																																																											
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2014	Acadia	Powertrain	Chassis Control Module																																																												
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
V	2014	Acadia	Chassis	Electronic Brake Control Module																																																												
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2014	Acadia	Body	Passenger Presence Module																																																												
V	2014	Acadia	Body	Instrument Cluster																																																												
V	2014	Acadia	Body	Head-Up Display Module																																																												
V	2014	Acadia	Body	Radio																																																												
V	2014	Acadia	Body	Rear Audio Control Module																																																												
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																												
V	2014	Acadia	Body	Personal Audio Link Control Module																																																												
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																												
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																												
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																												
V	2014	Acadia	Body	Liftgate Control Module																																																												
V	2014	Acadia	Body	Seat Memory Control Module																																																												
V	2014	Acadia	Body	Front Seat Heating Control Module																																																												
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																												
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																												
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																												
V	2014	Acadia	Body	Parking Assist Control Module																																																												
V	2014	Acadia	Body	Frontview Camera Module																																																												
V	2014	Acadia	Body	Theft Deterrent Module																																																												
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
V	2015	Acadia	Chassis	Electronic Brake Control Module																																																												
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2015	Acadia	Body	Passenger Presence Module																																																												
V	2015	Acadia	Body	Instrument Cluster																																																												
V	2015	Acadia	Body	Head-Up Display Module																																																												
V	2015	Acadia	Body	Radio																																																												
V	2015	Acadia	Body	Rear Audio Control Module																																																												
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																												
V	2015	Acadia	Body	Personal Audio Link Control Module																																																												
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																											
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																											
V	2015	Acadia	Body	Liftgate Control Module																																																											
V	2015	Acadia	Body	Seat Memory Control Module																																																											
V	2015	Acadia	Body	Front Seat Heating Control Module																																																											
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																											
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																											
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																											
V	2015	Acadia	Body	Parking Assist Control Module																																																											
V	2015	Acadia	Body	Frontview Camera Module																																																											
V	2015	Acadia	Body	Theft Deterrent Module																																																											
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																											
V	2016	Acadia	Chassis	Electronic Brake Control Module																																																											
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																											
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																											
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
V	2016	Acadia	Body	Passenger Presence Module																																																											
V	2016	Acadia	Body	Instrument Cluster																																																											
V	2016	Acadia	Body	Head-Up Display Module																																																											
V	2016	Acadia	Body	Radio																																																											
V	2016	Acadia	Body	Rear Audio Control Module																																																											
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																											
V	2016	Acadia	Body	Personal Audio Link Control Module																																																											
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																											
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																											
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																											
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																											
V	2016	Acadia	Body	Liftgate Control Module																																																											
V	2016	Acadia	Body	Seat Memory Control Module																																																											
V	2016	Acadia	Body	Front Seat Heating Control Module																																																											
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																											
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																											
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																											
V	2016	Acadia	Body	Parking Assist Control Module																																																											
V	2016	Acadia	Body	Frontview Camera Module																																																											
V	2016	Acadia	Body	Theft Deterrent Module																																																											
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																							
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																						
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module			V																																																							
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module			V																																																							
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																											
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
1	2011	Sierra	Chassis	Electronic Suspension Control																																																										
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																										
1	2011	Sierra	Body	Amplifier (Bose)																																																										
1	2011	Sierra	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
1	2011	Sierra	Body	Body Control Module (aux.)																																																										
1	2011	Sierra	Body	Digital Radio Receiver																																																										
1	2011	Sierra	Body	Driver Door Switch																																																										
1	2011	Sierra	Body	HVAC Control Module Auto																												V	V																														
1	2011	Sierra	Body	HVAC Control Module Manual																													V																														
1	2011	Sierra	Body	Instrument Panel Cluster																																																										
1	2011	Sierra	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
1	2011	Sierra	Body	Park Assist Module																																							V	V	V																	
1	2011	Sierra	Body	Passenger Door Switch																																																										
1	2011	Sierra	Body	Passenger Presence System																																										V																
1	2011	Sierra	Body	Radio																																																									
1	2011	Sierra	Body	Rear Heated Seat Module																																	V				V																					
1	2011	Sierra	Body	Rear HVAC/RSA																																																										
1	2011	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2011	Sierra	Body	Theft Deterrent Module																																																										
1	2011	Sierra Hybrid	Powertrain	Engine Control Module	V			V																																																							
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																							V																																				
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module		V																																																								
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																										
1	2011	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2011	Sierra Hybrid	Body	Driver Door Switch																																																										
1	2011	Sierra Hybrid	Body	Heated Seat Module																																	V				V																					
1	2011	Sierra Hybrid	Body	HVAC Control Module																												V	V																													
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2011	Sierra Hybrid	Body	Park Assist Module																																							V	V	V																	
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																																										
1	2011	Sierra Hybrid	Body	Passenger Presence System																																										V																
1	2011	Sierra Hybrid	Body	Radio																																																										
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																	V				V																					
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																						
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																								
1	2011	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2011	Yukon	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																										
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon	Body	Amplifier (Bose)																																																										
1	2011	Yukon	Body	Assist Step Controller																																																										
1	2011	Yukon	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
1	2011	Yukon	Body	Body Control Module (aux.)																																																										
1	2011	Yukon	Body	Digital Radio Receiver																																																										
1	2011	Yukon	Body	Driver Door Switch																																																										
1	2011	Yukon	Body	HVAC Control Module Auto																												V	V																													
1	2011	Yukon	Body	HVAC Control Module Manual																													V																													
1	2011	Yukon	Body	Instrument Panel Cluster																																																										
1	2011	Yukon	Body	Left Side Object Detection Module																																								V					V												
1	2011	Yukon	Body	Lift Gate Module																																																										
1	2011	Yukon	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				
1	2011	Yukon	Body	Park Assist Module																																							V	V	V																	
1	2011	Yukon	Body	Passenger Door Switch																																																										
1	2011	Yukon	Body	Passenger Presence System																																										V																
1	2011	Yukon	Body	Radio																																																										
1	2011	Yukon	Body	Rear Heated Seat Module																																	V				V																					
1	2011	Yukon	Body	Rear HVAC/RSA																																																										
1	2011	Yukon	Body	Right Side Object Detection Module																																								V					V												
1	2011	Yukon	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon	Body	Theft Deterrent Module																																																										
1	2011	Yukon Hybrid	Powertrain	Engine Control Module	V			V																																																						
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																							V																																			

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module		V																																																								
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2011	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2011	Yukon Hybrid	Body	Heated Seat Module																																	V				V																					
1	2011	Yukon Hybrid	Body	HVAC Control Module																												V	V																													
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																								V					V												
1	2011	Yukon Hybrid	Body	Lift Gate Module																																																										
1	2011	Yukon Hybrid	Body	Park Assist Module																																							V	V	V																		
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2011	Yukon Hybrid	Body	Passenger Presence System																																										V																
1	2011	Yukon Hybrid	Body	Radio																																																										
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																	V				V																					
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																								V					V												
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																						
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																								
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW														V																																											
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																										
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon XL	Body	Amplifier (Bose)																																																										
1	2011	Yukon XL	Body	Assist Step Controller																																																										
1	2011	Yukon XL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2011	Yukon XL	Body	Digital Radio Receiver																																																										
1	2011	Yukon XL	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2011	Yukon XL	Body	HVAC Control Module Auto																												V	V																												
1	2011	Yukon XL	Body	HVAC Control Module Manual																													V																												
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																									
1	2011	Yukon XL	Body	Left Side Object Detection Module																																								V					V												
1	2011	Yukon XL	Body	Lift Gate Module																																																								
1	2011	Yukon XL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																		
1	2011	Yukon XL	Body	Park Assist Module																																							V	V	V															
1	2011	Yukon XL	Body	Passenger Door Switch																																																								
1	2011	Yukon XL	Body	Passenger Presence System																																										V														
1	2011	Yukon XL	Body	Radio																																																								
1	2011	Yukon XL	Body	Rear Heated Seat Module																																	V			V																				
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																								
1	2011	Yukon XL	Body	Right Side Object Detection Module																																							V					V												
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
1	2011	Yukon XL	Body	Theft Deterrent Module																																																								
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																				
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																				
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																				
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																						
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																				
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																						
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																				
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																						
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																				
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																						
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module			V																																																				
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																								
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module			V																																																				
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																								
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																								
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																									
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
1	2012	Sierra	Chassis	Electronic Suspension Control																																																								
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																								
1	2012	Sierra	Body	Amplifier (Bose)																																																								
1	2012	Sierra	Body	Body Control Module															V	V	V	V	V		V		V	V			V																													
1	2012	Sierra	Body	Body Control Module (aux.)																																																								
1	2012	Sierra	Body	Digital Radio Receiver																																																								
1	2012	Sierra	Body	Driver Door Switch																																																								
1	2012	Sierra	Body	HVAC Control Module Auto																												V	V																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2012	Sierra	Body	HVAC Control Module Manual																													V																												
1	2012	Sierra	Body	Instrument Panel Cluster																																																									
1	2012	Sierra	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
1	2012	Sierra	Body	Park Assist Module																																							V	V	V																
1	2012	Sierra	Body	Passenger Door Switch																																																								
1	2012	Sierra	Body	Passenger Presence System																																										V															
1	2012	Sierra	Body	Radio																																																								
1	2012	Sierra	Body	Navigation Radio																																																								
1	2012	Sierra	Body	Rear Heated Seat Module																																	V				V																				
1	2012	Sierra	Body	Rear HVAC/RSA																																																								
1	2012	Sierra	Body	Supplemental Inflatable Restraint																																																								
1	2012	Sierra	Body	Theft Deterrent Module																																																								
1	2012	Sierra Hybrid	Powertrain	Engine Control Module	V			V																																																					
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																								
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																						V																																			
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module		V																																																						
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																								
1	2012	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																													
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																								
1	2012	Sierra Hybrid	Body	Driver Door Switch																																																								
1	2012	Sierra Hybrid	Body	Heated Seat Module																																	V				V																				
1	2012	Sierra Hybrid	Body	HVAC Control Module																												V	V																												
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
1	2012	Sierra Hybrid	Body	Park Assist Module																																							V	V	V																
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																																								
1	2012	Sierra Hybrid	Body	Passenger Presence System																																										V															
1	2012	Sierra Hybrid	Body	Radio																																																								
1	2012	Sierra Hybrid	Body	Navigation Radio																																																								
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																	V				V																				
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																								
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																					
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																							
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																				
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																							
1	2012	Yukon	Chassis	Electronic Brake Control Module																																																									
1	2012	Yukon	Chassis	Electronic Suspension Control																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																										
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Yukon	Body	Amplifier (Bose)																																																										
1	2012	Yukon	Body	Assist Step Controller																																																										
1	2012	Yukon	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
1	2012	Yukon	Body	Body Control Module (aux.)																																																										
1	2012	Yukon	Body	Digital Radio Receiver																																																										
1	2012	Yukon	Body	Driver Door Switch																																																										
1	2012	Yukon	Body	HVAC Control Module Auto																												V	V																														
1	2012	Yukon	Body	HVAC Control Module Manual																													V																														
1	2012	Yukon	Body	Instrument Panel Cluster																																																										
1	2012	Yukon	Body	Left Side Object Detection Module																																								V					V													
1	2012	Yukon	Body	Lift Gate Module																																																										
1	2012	Yukon	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				
1	2012	Yukon	Body	Park Assist Module																																							V	V	V																	
1	2012	Yukon	Body	Passenger Door Switch																																																										
1	2012	Yukon	Body	Passenger Presence System																																										V																	
1	2012	Yukon	Body	Radio																																																										
1	2012	Yukon	Body	Navigation Radio																																																										
1	2012	Yukon	Body	Rear Heated Seat Module																																	V				V																						
1	2012	Yukon	Body	Rear HVAC/RSA																																																										
1	2012	Yukon	Body	Right Side Object Detection Module																																								V					V													
1	2012	Yukon	Body	Supplemental Inflatable Restraint																																																										
1	2012	Yukon	Body	Theft Deterrent Module																																																										
1	2012	Yukon Hybrid	Powertrain	Engine Control Module	V			V																																																							
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																							V																																				
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module		V																																																									
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																											
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																											
1	2012	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																											
1	2012	Yukon Hybrid	Body	Driver Door Switch																																																											
1	2012	Yukon Hybrid	Body	Heated Seat Module																																	V				V																						
1	2012	Yukon Hybrid	Body	HVAC Control Module																												V	V																														
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																								V					V													
1	2012	Yukon Hybrid	Body	Lift Gate Module																																																											
1	2012	Yukon Hybrid	Body	Park Assist Module																																							V	V	V																	
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																																											
1	2012	Yukon Hybrid	Body	Passenger Presence System																																										V																	

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2012	Yukon Hybrid	Body	Radio																																																												
1	2012	Yukon Hybrid	Body	Navigation Radio																																																												
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																		V				V																						
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																								V				V																
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																												
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																								
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																										
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																								
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																										
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																								
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																										
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																								
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																										
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW														V																																														
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																												
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																												
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
1	2012	Yukon XL	Body	Amplifier (Bose)																																																												
1	2012	Yukon XL	Body	Assist Step Controller																																																												
1	2012	Yukon XL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																	
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																												
1	2012	Yukon XL	Body	Digital Radio Receiver																																																												
1	2012	Yukon XL	Body	Driver Door Switch																																																												
1	2012	Yukon XL	Body	HVAC Control Module Auto																												V	V																															
1	2012	Yukon XL	Body	HVAC Control Module Manual																													V																															
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																												
1	2012	Yukon XL	Body	Left Side Object Detection Module																																								V				V																
1	2012	Yukon XL	Body	Lift Gate Module																																																												
1	2012	Yukon XL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				
1	2012	Yukon XL	Body	Park Assist Module																																							V	V	V																			
1	2012	Yukon XL	Body	Passenger Door Switch																																																												
1	2012	Yukon XL	Body	Passenger Presence System																																										V																		
1	2012	Yukon XL	Body	Radio																																																												
1	2012	Yukon XL	Body	Navigation Radio																																																												
1	2012	Yukon XL	Body	Rear Heated Seat Module																																		V				V																						
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																												
1	2012	Yukon XL	Body	Right Side Object Detection Module																																								V				V																
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
1	2012	Yukon XL	Body	Theft Deterrent Module																																																												
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																								
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																								
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																					
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																							
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																					
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																							
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																					
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																							
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																					
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																									
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																							
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																					
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																							
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																									
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																									
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																									
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module			V																																																						
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES														V																																											
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES														V																																											
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																									
1	2013	Sierra	Chassis	Electronic Suspension Control																																																									
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Sierra	Body	Amplifier (Bose)																																																									
1	2013	Sierra	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
1	2013	Sierra	Body	Body Control Module (aux.)																																																									
1	2013	Sierra	Body	Digital Radio Receiver																																																									
1	2013	Sierra	Body	Driver Door Switch																																																									
1	2013	Sierra	Body	HVAC Control Module Auto																												V	V																												
1	2013	Sierra	Body	HVAC Control Module Manual																													V																												
1	2013	Sierra	Body	Instrument Panel Cluster																																																									
1	2013	Sierra	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
1	2013	Sierra	Body	Park Assist Module																																						V	V	V																	
1	2013	Sierra	Body	Passenger Door Switch																																																									
1	2013	Sierra	Body	Passenger Presence System																																									V																
1	2013	Sierra	Body	Radio																																																								
1	2013	Sierra	Body	Navigation Radio																																																									
1	2013	Sierra	Body	Rear Heated Seat Module																																	V				V																				
1	2013	Sierra	Body	Rear HVAC/RSA																																																									
1	2013	Sierra	Body	Supplemental Inflatable Restraint																																																									
1	2013	Sierra	Body	Theft Deterrent Module																																																									
1	2013	Sierra Hybrid	Powertrain	Engine Control Module	V			V																																																					
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																									
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																									
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																									
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																							V																																		
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																									
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																									
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module		V																																																							

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																											
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																											
1	2013	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																											
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																											
1	2013	Sierra Hybrid	Body	Driver Door Switch																																																											
1	2013	Sierra Hybrid	Body	Heated Seat Module																																	V				V																						
1	2013	Sierra Hybrid	Body	HVAC Control Module																												V	V																														
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																											
1	2013	Sierra Hybrid	Body	Park Assist Module																																							V	V	V																		
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																																											
1	2013	Sierra Hybrid	Body	Passenger Presence System																																										V																	
1	2013	Sierra Hybrid	Body	Radio																																																											
1	2013	Sierra Hybrid	Body	Navigation Radio																																																												
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																	V				V																						
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																											
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																											
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																											
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																											
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																							
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																									
1	2013	Yukon	Chassis	Electronic Brake Control Module														V																																													
1	2013	Yukon	Chassis	Electronic Suspension Control																																																												
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Yukon	Body	Amplifier (Bose)																																																											
1	2013	Yukon	Body	Assist Step Controller																																																											
1	2013	Yukon	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
1	2013	Yukon	Body	Body Control Module (aux.)																																																											
1	2013	Yukon	Body	Digital Radio Receiver																																																											
1	2013	Yukon	Body	Driver Door Switch																																																											
1	2013	Yukon	Body	HVAC Control Module Auto																												V	V																														
1	2013	Yukon	Body	HVAC Control Module Manual																													V																														
1	2013	Yukon	Body	Instrument Panel Cluster																																																											
1	2013	Yukon	Body	Left Side Object Detection Module																																								V					V													
1	2013	Yukon	Body	Lift Gate Module																																																											
1	2013	Yukon	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																				
1	2013	Yukon	Body	Park Assist Module																																							V	V	V																	
1	2013	Yukon	Body	Passenger Door Switch																																																											
1	2013	Yukon	Body	Passenger Presence System																																										V																	
1	2013	Yukon	Body	Radio																																																											
1	2013	Yukon	Body	Navigation Radio																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2013	Yukon	Body	Rear Heated Seat Module																																	V				V																				
1	2013	Yukon	Body	Rear HVAC/RSA																																																									
1	2013	Yukon	Body	Right Side Object Detection Module																																								V					V												
1	2013	Yukon	Body	Supplemental Inflatable Restraint																																																								
1	2013	Yukon	Body	Theft Deterrent Module																																																								
1	2013	Yukon Hybrid	Powertrain	Engine Control Module	V			V																																																					
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																									
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																									
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																									
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																							V																																			
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																									
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																									
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module		V																																																							
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																									
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																									
1	2013	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																									
1	2013	Yukon Hybrid	Body	Driver Door Switch																																																									
1	2013	Yukon Hybrid	Body	Heated Seat Module																																	V				V																					
1	2013	Yukon Hybrid	Body	HVAC Control Module																												V	V																													
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																								V					V												
1	2013	Yukon Hybrid	Body	Lift Gate Module																																																									
1	2013	Yukon Hybrid	Body	Park Assist Module																																							V	V	V																	
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																																									
1	2013	Yukon Hybrid	Body	Passenger Presence System																																										V															
1	2013	Yukon Hybrid	Body	Radio																																																									
1	2013	Yukon Hybrid	Body	Navigation Radio																																																									
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																	V				V																					
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																								V					V												
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																									
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																					
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																							
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																					
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																							
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																					
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																							
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																					
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																								
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW														V																																											
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW														V																																											
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon XL	Body	Amplifier (Bose)																																																										
1	2013	Yukon XL	Body	Assist Step Controller																																																										
1	2013	Yukon XL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2013	Yukon XL	Body	Digital Radio Receiver																																																										
1	2013	Yukon XL	Body	Driver Door Switch																																																										
1	2013	Yukon XL	Body	HVAC Control Module Auto																												V	V																														
1	2013	Yukon XL	Body	HVAC Control Module Manual																													V																														
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																										
1	2013	Yukon XL	Body	Left Side Object Detection Module																																								V					V													
1	2013	Yukon XL	Body	Lift Gate Module																																																										
1	2013	Yukon XL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																					
1	2013	Yukon XL	Body	Park Assist Module																																							V	V	V																	
1	2013	Yukon XL	Body	Passenger Door Switch																																																										
1	2013	Yukon XL	Body	Passenger Presence System																																										V																
1	2013	Yukon XL	Body	Radio																																																										
1	2013	Yukon XL	Body	Navigation Radio																																																										
1	2013	Yukon XL	Body	Rear Heated Seat Module																																	V				V																					
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																										
1	2013	Yukon XL	Body	Right Side Object Detection Module																																								V					V													
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
1	2013	Yukon XL	Body	Theft Deterrent Module																																																											
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																											
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2014	Sierra	Chassis	Electronic Brake Control Module																																																											
1	2014	Sierra	Chassis	Parking Brake Control Module																																																											
1	2014	Sierra	Chassis	Power Steering Control Module																																																											
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Sierra	Body	Body Control Module																																																											
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	Sierra	Body	Passenger Presence Module																																																											
1	2014	Sierra	Body	Instrument Cluster																																																											
1	2014	Sierra	Body	Radio Control																																																											
1	2014	Sierra	Body	HVAC Control																																																											
1	2014	Sierra	Body	Radio																																																											
1	2014	Sierra	Body	Amplifier																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2014	Sierra	Body	Media Disc Player																																																										
1	2014	Sierra	Body	Human Machine Interface Control Module																																																											
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
1	2014	Sierra	Body	Parking Assist Control Module																																																											
1	2014	Sierra	Body	Frontview Camera Module																																																											
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																											
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																											
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																											
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																											
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																											
1	2014	Sierra HD	Chassis	Suspension Control Module																																																											
1	2014	Sierra HD	Body	Body Control Module																																																											
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	Sierra HD	Body	Instrument Cluster																																																											
1	2014	Sierra HD	Body	Base Radio																																																											
1	2014	Sierra HD	Body	Navigation Radio																																																											
1	2014	Sierra HD	Body	Uplevel Radio																																																											
1	2014	Sierra HD	Body	Amplifier																																																											
1	2014	Sierra HD	Body	Rear Audio Control Module																																																											
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																											
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																											
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																											
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																											
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																											
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																											
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																											
1	2014	Sierra HD	Body	Seat Memory Control Module																																																											
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																											
1	2014	Sierra HD	Body	Parking Assist Control Module																																																											
1	2014	Sierra HD	Body	Theft Deterrent Module																																																											
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																											
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																											
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																											
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																											
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2014	Yukon	Chassis	Electronic Brake Control Module																																																											
1	2014	Yukon	Chassis	Parking Brake Control Module																																																										
1	2014	Yukon	Chassis	Suspension Control Module																																																										
1	2014	Yukon	Body	Body Control Module																																																										
1	2014	Yukon	Body	Auxiliary Body Control Module																																																										
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Yukon	Body	Passenger Presence Module																																																										
1	2014	Yukon	Body	Instrument Cluster																																																										
1	2014	Yukon	Body	Base Radio																																																										
1	2014	Yukon	Body	Navigation Radio																																																										
1	2014	Yukon	Body	Uplevel Radio																																																										
1	2014	Yukon	Body	Amplifier																																																										
1	2014	Yukon	Body	Rear Audio Control Module																																																										
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																																										
1	2014	Yukon	Body	Personal Audio Link Control Module																																																										
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Yukon	Body	Liftgate Control Module																																																										
1	2014	Yukon	Body	Seat Memory Control Module																																																										
1	2014	Yukon	Body	Rear Seat Heating Control Module																																																										
1	2014	Yukon	Body	Assist Step Control Module																																																										
1	2014	Yukon	Body	Right Side Object Detection Control Module																																																										
1	2014	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																																										
1	2014	Yukon	Body	Parking Assist Control Module																																																										
1	2014	Yukon	Body	Theft Deterrent Module																																																										
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																										
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2014	Yukon XL	Chassis	Suspension Control Module																																																										
1	2014	Yukon XL	Body	Body Control Module																																																										
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																																										
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Yukon XL	Body	Passenger Presence Module																																																										
1	2014	Yukon XL	Body	Instrument Cluster																																																										
1	2014	Yukon XL	Body	Base Radio																																																										
1	2014	Yukon XL	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2014	Yukon XL	Body	Uplevel Radio																																																										
1	2014	Yukon XL	Body	Amplifier																																																										
1	2014	Yukon XL	Body	Rear Audio Control Module																																																										
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																										
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																																										
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Yukon XL	Body	Liftgate Control Module																																																										
1	2014	Yukon XL	Body	Seat Memory Control Module																																																										
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																										
1	2014	Yukon XL	Body	Assist Step Control Module																																																										
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																										
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																										
1	2014	Yukon XL	Body	Parking Assist Control Module																																																										
1	2014	Yukon XL	Body	Theft Deterrent Module																																																										
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Sierra	Chassis	Power Steering Control Module																																																										
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Sierra	Chassis	Suspension Control Module																																																										
1	2015	Sierra	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Sierra	Body	Passenger Presence Module																																																											
1	2015	Sierra	Body	Instrument Cluster																																																											
1	2015	Sierra	Body	Radio Controls																																																											
1	2015	Sierra	Body	HVAC Controls																																																											
1	2015	Sierra	Body	Radio																																																											
1	2015	Sierra	Body	Amplifier																																																											
1	2015	Sierra	Body	Media Disc Player																																																											
1	2015	Sierra	Body	Human Machine Interface Control Module																																																											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
1	2015	Sierra	Body	Parking Assist Control Module																																																											
1	2015	Sierra	Body	Frontview Camera Module																																																											
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																											
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																											
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																											
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																											
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																											
1	2015	Yukon	Chassis	Electronic Brake Control Module																																																											
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																											
1	2015	Yukon	Chassis	Parking Brake Control Module																																																											
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2015	Yukon	Chassis	Power Steering Control Module																																																											
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2015	Yukon	Chassis	Suspension Control Module																																																											
1	2015	Yukon	Body	Body Control Module																																																											
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	Yukon	Body	Passenger Presence Module																																																											
1	2015	Yukon	Body	Instrument Cluster																																																											
1	2015	Yukon	Body	Radio Controls																																																											
1	2015	Yukon	Body	HVAC Controls																																																											
1	2015	Yukon	Body	Radio																																																											
1	2015	Yukon	Body	Amplifier																																																											
1	2015	Yukon	Body	Media Disc Player																																																											
1	2015	Yukon	Body	Human Machine Interface Control Module																																																											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2015	Yukon	Body	HVAC Control Module																																																										
1	2015	Yukon	Body	Liftgate Control Module																																																											
1	2015	Yukon	Body	Keyless Entry Control Module																																																											
1	2015	Yukon	Body	Assist Step Control Module																																																											
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																											
1	2015	Yukon	Body	Parking Assist Control Module																																																											
1	2015	Yukon	Body	Frontview Camera Module																																																											
1	2015	Yukon	Body	Steering Column Lock Control Module																																																											
1	2015	Yukon	Body	Battery Energy Control Module																																																											
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																											
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																											
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																											
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																											
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																											
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2015	Yukon XL	Chassis	Power Steering Control Module																																																											
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2015	Yukon XL	Chassis	Suspension Control Module																																																											
1	2015	Yukon XL	Body	Body Control Module																																																											
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	Yukon XL	Body	Passenger Presence Module																																																											
1	2015	Yukon XL	Body	Instrument Cluster																																																											
1	2015	Yukon XL	Body	Radio Controls																																																											
1	2015	Yukon XL	Body	HVAC Controls																																																											
1	2015	Yukon XL	Body	Radio																																																											
1	2015	Yukon XL	Body	Amplifier																																																											
1	2015	Yukon XL	Body	Media Disc Player																																																											
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																											
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																											
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2015	Yukon XL	Body	HVAC Control Module																																																											
1	2015	Yukon XL	Body	Liftgate Control Module																																																											
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																											
1	2015	Yukon XL	Body	Assist Step Control Module																																																											
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																											
1	2015	Yukon XL	Body	Parking Assist Control Module																																																											
1	2015	Yukon XL	Body	Frontview Camera Module																																																											
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																											
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2016	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Sierra	Chassis	Parking Brake Control Module																																																										
1	2016	Sierra	Chassis	Power Steering Control Module																																																										
1	2016	Sierra	Chassis	Power Steering Control Module																																																										
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Sierra	Chassis	Suspension Control Module																																																										
1	2016	Sierra	Body	Body Control Module																																																										
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Sierra	Body	Passenger Presence Module																																																										
1	2016	Sierra	Body	Instrument Cluster																																																										
1	2016	Sierra	Body	Radio Controls																																																										
1	2016	Sierra	Body	HVAC Controls																																																										
1	2016	Sierra	Body	Radio (IO3)																																																										
1	2016	Sierra	Body	Radio (IOB)																																																										
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
1	2016	Sierra	Body	Amplifier																																																										
1	2016	Sierra	Body	Media Disc Player																																																										
1	2016	Sierra	Body	Human Machine Interface Control Module																																																										
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																										
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																										
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																										
1	2016	Sierra	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2016	Sierra	Body	Frontview Camera Module																																																										
1	2016	Sierra	Body	Frontview Camera Module																																																											
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2016	Yukon	Chassis	Electronic Brake Control Module																																																											
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																											
1	2016	Yukon	Chassis	Parking Brake Control Module																																																											
1	2016	Yukon	Chassis	Power Steering Control Module																																																											
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	Yukon	Chassis	Suspension Control Module																																																											
1	2016	Yukon	Body	Body Control Module																																																											
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2016	Yukon	Body	Passenger Presence Module																																																											
1	2016	Yukon	Body	Instrument Cluster																																																											
1	2016	Yukon	Body	Radio Controls																																																											
1	2016	Yukon	Body	HVAC Controls																																																											
1	2016	Yukon	Body	Radio																																																											
1	2016	Yukon	Body	Amplifier																																																											
1	2016	Yukon	Body	Media Disc Player																																																											
1	2016	Yukon	Body	Human Machine Interface Control Module																																																											
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																											
1	2016	Yukon	Body	HVAC Control Module																																																											
1	2016	Yukon	Body	Liftgate Control Module																																																											
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																											
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																											
1	2016	Yukon	Body	Keyless Entry Control Module																																																											
1	2016	Yukon	Body	Assist Step Control Module																																																											
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																											
1	2016	Yukon	Body	Parking Assist Control Module																																																											
1	2016	Yukon	Body	Frontview Camera Module																																																											
1	2016	Yukon	Body	Steering Column Lock Control Module																																																											
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																											
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																											
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																											
1	2016	Yukon XL	Chassis	Power Steering Control Module																																																											
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	Yukon XL	Chassis	Suspension Control Module																																																											
1	2016	Yukon XL	Body	Body Control Module																																																											
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
1	2016	Yukon XL	Body	Passenger Presence Module																																																										
1	2016	Yukon XL	Body	Instrument Cluster																																																										
1	2016	Yukon XL	Body	Radio Controls																																																										
1	2016	Yukon XL	Body	HVAC Controls																																																										
1	2016	Yukon XL	Body	Radio																																																										
1	2016	Yukon XL	Body	Amplifier																																																										
1	2016	Yukon XL	Body	Media Disc Player																																																										
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																										
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																										
1	2016	Yukon XL	Body	HVAC Control Module																																																										
1	2016	Yukon XL	Body	Liftgate Control Module																																																										
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																										
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																										
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																										
1	2016	Yukon XL	Body	Assist Step Control Module																																																										
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2016	Yukon XL	Body	Parking Assist Control Module																																																										
1	2016	Yukon XL	Body	Frontview Camera Module																																																										
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																										
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																														
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module											V																																														
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																						
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module											V																																														
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																														
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																														
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																						
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																														
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module			V																																																						
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module											V																																														
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module			V																																																						
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module											V																																														

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																											
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
2	2011	Sierra	Chassis	Electronic Suspension Control																																																										
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																										
2	2011	Sierra	Body	Amplifier (Bose)																																																										
2	2011	Sierra	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
2	2011	Sierra	Body	Body Control Module (aux.)																																																										
2	2011	Sierra	Body	Digital Radio Receiver																																																										
2	2011	Sierra	Body	Driver Door Switch																																																										
2	2011	Sierra	Body	HVAC Control Module Auto																												V	V																														
2	2011	Sierra	Body	HVAC Control Module Manual																													V																														
2	2011	Sierra	Body	Instrument Panel Cluster																																																										
2	2011	Sierra	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																					
2	2011	Sierra	Body	Park Assist Module																																								V	V	V																
2	2011	Sierra	Body	Passenger Door Switch																																																										
2	2011	Sierra	Body	Passenger Presence System																																											V															
2	2011	Sierra	Body	Radio																																																										
2	2011	Sierra	Body	Rear Heated Seat Module																																	V				V																					
2	2011	Sierra	Body	Rear HVAC/RSA																																																										
2	2011	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2011	Sierra	Body	Theft Deterrent Module																																																										
2	2011	Sierra Hybrid	Powertrain	Engine Control Module	V			V																																																						
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																							V																																			
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module		V																																																								
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module										V																																																
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2011	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2011	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2011	Sierra Hybrid	Body	Heated Seat Module																																	V				V																					
2	2011	Sierra Hybrid	Body	HVAC Control Module																												V	V																													
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2011	Sierra Hybrid	Body	Park Assist Module																																							V	V	V																	
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2011	Sierra Hybrid	Body	Passenger Presence System																																										V															
2	2011	Sierra Hybrid	Body	Radio																																																										
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																	V				V																					
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																											
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																											
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																											
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module											V																																																
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module											V																																																
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																							
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																									
2	2011	Yukon	Chassis	Electronic Brake Control Module																																																											
2	2011	Yukon	Chassis	Electronic Suspension Control																																																											
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																											
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
2	2011	Yukon	Body	Amplifier (Bose)																																																											
2	2011	Yukon	Body	Assist Step Controller																																																											
2	2011	Yukon	Body	Body Control Module														V	V	V	V	V		V		V	V			V																																	
2	2011	Yukon	Body	Body Control Module (aux.)																																																											
2	2011	Yukon	Body	Digital Radio Receiver																																																											
2	2011	Yukon	Body	Driver Door Switch																																																											
2	2011	Yukon	Body	HVAC Control Module Auto																												V	V																														
2	2011	Yukon	Body	HVAC Control Module Manual																													V																														
2	2011	Yukon	Body	Instrument Panel Cluster																																																											
2	2011	Yukon	Body	Left Side Object Detection Module																																							V				V																
2	2011	Yukon	Body	Lift Gate Module																																																											
2	2011	Yukon	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																					
2	2011	Yukon	Body	Park Assist Module																																							V	V	V																		
2	2011	Yukon	Body	Passenger Door Switch																																																											
2	2011	Yukon	Body	Passenger Presence System																																										V																	
2	2011	Yukon	Body	Radio																																																											
2	2011	Yukon	Body	Rear Heated Seat Module																																	V			V																							
2	2011	Yukon	Body	Rear HVAC/RSA																																																											
2	2011	Yukon	Body	Right Side Object Detection Module																																							V				V																
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																																											
2	2011	Yukon	Body	Theft Deterrent Module																																																											
2	2011	Yukon Hybrid	Powertrain	Engine Control Module	V			V																																																							
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																							V																																				
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module		V																																																									
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module											V																																																
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																											
2	2011	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																											
2	2011	Yukon Hybrid	Body	Driver Door Switch																																																											
2	2011	Yukon Hybrid	Body	Heated Seat Module																																	V				V																						
2	2011	Yukon Hybrid	Body	HVAC Control Module																												V	V																														
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																							V					V														
2	2011	Yukon Hybrid	Body	Lift Gate Module																																																											
2	2011	Yukon Hybrid	Body	Park Assist Module																																						V	V	V																			
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																																											
2	2011	Yukon Hybrid	Body	Passenger Presence System																																									V																		
2	2011	Yukon Hybrid	Body	Radio																																																											
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																	V				V																						
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																							V					V														
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																											
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module	V			V																																																							
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module		V																																																									
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module											V																																																
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module											V																																																
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																							
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																									
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module											V																																																
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module											V																																																
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																																
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																							
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																									
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW														V																																													
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																												
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																												
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
2	2011	Yukon XL	Body	Amplifier (Bose)																																																												
2	2011	Yukon XL	Body	Assist Step Controller																																																												
2	2011	Yukon XL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																												
2	2011	Yukon XL	Body	Digital Radio Receiver																																																												
2	2011	Yukon XL	Body	Driver Door Switch																																																												
2	2011	Yukon XL	Body	HVAC Control Module Auto																												V	V																															
2	2011	Yukon XL	Body	HVAC Control Module Manual																													V																															
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																												
2	2011	Yukon XL	Body	Left Side Object Detection Module																																							V					V														

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2011	Yukon XL	Body	Lift Gate Module																																																									
2	2011	Yukon XL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																			
2	2011	Yukon XL	Body	Park Assist Module																																							V	V	V																
2	2011	Yukon XL	Body	Passenger Door Switch																																																								
2	2011	Yukon XL	Body	Passenger Presence System																																										V															
2	2011	Yukon XL	Body	Radio																																																								
2	2011	Yukon XL	Body	Rear Heated Seat Module																																	V			V																					
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																								
2	2011	Yukon XL	Body	Right Side Object Detection Module																																							V					V													
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
2	2011	Yukon XL	Body	Theft Deterrent Module																																																									
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																					
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																														
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																					
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module											V																																														
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																					
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																							
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module											V																																														
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																					
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																							
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																														
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																					
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																							
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																														
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																					
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																							
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																														
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																									
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																									
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module			V																																																						
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module											V																																														
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																									
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																									
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																									
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module			V																																																						
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module											V																																														
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																									
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																									
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES														V																																										
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
2	2012	Sierra	Chassis	Electronic Suspension Control																																																									
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																									
2	2012	Sierra	Body	Amplifier (Bose)																																																									
2	2012	Sierra	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2012	Sierra	Body	Body Control Module (aux.)																																																									
2	2012	Sierra	Body	Digital Radio Receiver																																																										
2	2012	Sierra	Body	Driver Door Switch																																																										
2	2012	Sierra	Body	HVAC Control Module Auto																											V	V																														
2	2012	Sierra	Body	HVAC Control Module Manual																												V																														
2	2012	Sierra	Body	Instrument Panel Cluster																																																										
2	2012	Sierra	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
2	2012	Sierra	Body	Park Assist Module																																							V	V	V																	
2	2012	Sierra	Body	Passenger Door Switch																																																										
2	2012	Sierra	Body	Passenger Presence System																																										V																
2	2012	Sierra	Body	Radio																																																										
2	2012	Sierra	Body	Navigation Radio																																																										
2	2012	Sierra	Body	Rear Heated Seat Module																																	V				V																					
2	2012	Sierra	Body	Rear HVAC/RSA																																																										
2	2012	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra	Body	Theft Deterrent Module																																																										
2	2012	Sierra Hybrid	Powertrain	Engine Control Module	V			V																																																						
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																						V																																				
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module		V																																																								
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module										V																																																
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																															
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2012	Sierra Hybrid	Body	Heated Seat Module																																	V				V																					
2	2012	Sierra Hybrid	Body	HVAC Control Module																											V	V																														
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2012	Sierra Hybrid	Body	Park Assist Module																																							V	V	V																	
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2012	Sierra Hybrid	Body	Passenger Presence System																																										V																
2	2012	Sierra Hybrid	Body	Radio																																																										
2	2012	Sierra Hybrid	Body	Navigation Radio																																																										
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																	V				V																					
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																						
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module											V																																															
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module											V																																															
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																						
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																									
2	2012	Yukon	Chassis	Electronic Brake Control Module																																																											
2	2012	Yukon	Chassis	Electronic Suspension Control																																																											
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																											
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
2	2012	Yukon	Body	Amplifier (Bose)																																																											
2	2012	Yukon	Body	Assist Step Controller																																																											
2	2012	Yukon	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
2	2012	Yukon	Body	Body Control Module (aux.)																																																											
2	2012	Yukon	Body	Digital Radio Receiver																																																											
2	2012	Yukon	Body	Driver Door Switch																																																											
2	2012	Yukon	Body	HVAC Control Module Auto																												V	V																														
2	2012	Yukon	Body	HVAC Control Module Manual																													V																														
2	2012	Yukon	Body	Instrument Panel Cluster																																																											
2	2012	Yukon	Body	Left Side Object Detection Module																																								V					V													
2	2012	Yukon	Body	Lift Gate Module																																																											
2	2012	Yukon	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																					
2	2012	Yukon	Body	Park Assist Module																																							V	V	V																	
2	2012	Yukon	Body	Passenger Door Switch																																																											
2	2012	Yukon	Body	Passenger Presence System																																									V																	
2	2012	Yukon	Body	Radio																																																											
2	2012	Yukon	Body	Navigation Radio																																																											
2	2012	Yukon	Body	Rear Heated Seat Module																																	V				V																					
2	2012	Yukon	Body	Rear HVAC/RSA																																																											
2	2012	Yukon	Body	Right Side Object Detection Module																																								V					V													
2	2012	Yukon	Body	Supplemental Inflatable Restraint																																																											
2	2012	Yukon	Body	Theft Deterrent Module																																																											
2	2012	Yukon Hybrid	Powertrain	Engine Control Module	V			V																																																							
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																						V																																					
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module		V																																																									
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module											V																																																
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																											
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																											
2	2012	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																											
2	2012	Yukon Hybrid	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2012	Yukon Hybrid	Body	Heated Seat Module																																	V				V																				
2	2012	Yukon Hybrid	Body	HVAC Control Module																											V	V																												
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																							V				V													
2	2012	Yukon Hybrid	Body	Lift Gate Module																																																								
2	2012	Yukon Hybrid	Body	Park Assist Module																																						V	V	V																	
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																																								
2	2012	Yukon Hybrid	Body	Passenger Presence System																																									V															
2	2012	Yukon Hybrid	Body	Radio																																																								
2	2012	Yukon Hybrid	Body	Navigation Radio																																																								
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																	V				V																				
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																							V				V													
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																								
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																				
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																						
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module										V																																														
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module										V																																														
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																				
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																						
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module										V																																														
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module										V																																														
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																				
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																						
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module										V																																														
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																				
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module		V																																																						
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																								
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW														V																																									
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																								
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																								
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
2	2012	Yukon XL	Body	Amplifier (Bose)																																																								
2	2012	Yukon XL	Body	Assist Step Controller																																																								
2	2012	Yukon XL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																													
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																								
2	2012	Yukon XL	Body	Digital Radio Receiver																																																								
2	2012	Yukon XL	Body	Driver Door Switch																																																								
2	2012	Yukon XL	Body	HVAC Control Module Auto																												V	V																												
2	2012	Yukon XL	Body	HVAC Control Module Manual																													V																												
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																								
2	2012	Yukon XL	Body	Left Side Object Detection Module																																							V				V													
2	2012	Yukon XL	Body	Lift Gate Module																																																								
2	2012	Yukon XL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																		
2	2012	Yukon XL	Body	Park Assist Module																																						V	V	V																
2	2012	Yukon XL	Body	Passenger Door Switch																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2012	Yukon XL	Body	Passenger Presence System																																										V															
2	2012	Yukon XL	Body	Radio																																																								
2	2012	Yukon XL	Body	Navigation Radio																																																								
2	2012	Yukon XL	Body	Rear Heated Seat Module																																	V				V																			
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																								
2	2012	Yukon XL	Body	Right Side Object Detection Module																																							V					V												
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
2	2012	Yukon XL	Body	Theft Deterrent Module																																																								
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																				
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module											V																																													
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																				
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module											V																																													
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																				
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																						
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module											V																																													
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																				
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																						
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module											V																																													
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																				
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																						
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module											V																																													
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																				
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																					
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module											V																																													
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module	V			V																																																				
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module		V																																																						
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module											V																																													
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module			V																																																					
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module											V																																													
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES														V																																										
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES														V																																									
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																								
2	2013	Sierra	Chassis	Electronic Suspension Control																																																								
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra	Body	Amplifier (Bose)																																																								
2	2013	Sierra	Body	Body Control Module															V	V	V	V	V		V		V	V			V																													
2	2013	Sierra	Body	Body Control Module (aux.)																																																								
2	2013	Sierra	Body	Digital Radio Receiver																																																								
2	2013	Sierra	Body	Driver Door Switch																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2013	Sierra	Body	HVAC Control Module Auto																												V	V																											
2	2013	Sierra	Body	HVAC Control Module Manual																													V																												
2	2013	Sierra	Body	Instrument Panel Cluster																																																								
2	2013	Sierra	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																			
2	2013	Sierra	Body	Park Assist Module																																						V	V	V																
2	2013	Sierra	Body	Passenger Door Switch																																																								
2	2013	Sierra	Body	Passenger Presence System																																									V															
2	2013	Sierra	Body	Radio																																																								
2	2013	Sierra	Body	Navigation Radio																																																								
2	2013	Sierra	Body	Rear Heated Seat Module																																	V			V																					
2	2013	Sierra	Body	Rear HVAC/RSA																																																								
2	2013	Sierra	Body	Supplemental Inflatable Restraint																																																								
2	2013	Sierra	Body	Theft Deterrent Module																																																								
2	2013	Sierra Hybrid	Powertrain	Engine Control Module	V			V																																																				
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																								
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																							V																																		
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module		V																																																						
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module											V																																													
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																								
2	2013	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																												
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																								
2	2013	Sierra Hybrid	Body	Driver Door Switch																																																								
2	2013	Sierra Hybrid	Body	Heated Seat Module																																	V			V																					
2	2013	Sierra Hybrid	Body	HVAC Control Module																												V	V																												
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
2	2013	Sierra Hybrid	Body	Park Assist Module																																						V	V	V																
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																																								
2	2013	Sierra Hybrid	Body	Passenger Presence System																																									V															
2	2013	Sierra Hybrid	Body	Radio																																																								
2	2013	Sierra Hybrid	Body	Navigation Radio																																																								
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																	V			V																				
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																				
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																						
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module											V																																													
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module											V																																													

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																					
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module		V																																																							
2	2013	Yukon	Chassis	Electronic Brake Control Module														V																																											
2	2013	Yukon	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon	Body	Amplifier (Bose)																																																									
2	2013	Yukon	Body	Assist Step Controller																																																									
2	2013	Yukon	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
2	2013	Yukon	Body	Body Control Module (aux.)																																																									
2	2013	Yukon	Body	Digital Radio Receiver																																																									
2	2013	Yukon	Body	Driver Door Switch																																																									
2	2013	Yukon	Body	HVAC Control Module Auto																												V	V																												
2	2013	Yukon	Body	HVAC Control Module Manual																													V																												
2	2013	Yukon	Body	Instrument Panel Cluster																																																									
2	2013	Yukon	Body	Left Side Object Detection Module																																								V					V												
2	2013	Yukon	Body	Lift Gate Module																																																									
2	2013	Yukon	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																			
2	2013	Yukon	Body	Park Assist Module																																							V	V	V																
2	2013	Yukon	Body	Passenger Door Switch																																																									
2	2013	Yukon	Body	Passenger Presence System																																										V															
2	2013	Yukon	Body	Radio																																																									
2	2013	Yukon	Body	Navigation Radio																																																									
2	2013	Yukon	Body	Rear Heated Seat Module																																	V			V																					
2	2013	Yukon	Body	Rear HVAC/RSA																																																									
2	2013	Yukon	Body	Right Side Object Detection Module																																								V					V												
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																																									
2	2013	Yukon	Body	Theft Deterrent Module																																																									
2	2013	Yukon Hybrid	Powertrain	Engine Control Module	V			V																																																						
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																									
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																									
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																									
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																							V																																		
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																									
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																									
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module		V																																																							
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module										V																																															
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																									
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																									
2	2013	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																									
2	2013	Yukon Hybrid	Body	Driver Door Switch																																																									
2	2013	Yukon Hybrid	Body	Heated Seat Module																																	V			V																					

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2013	Yukon Hybrid	Body	HVAC Control Module																												V	V																												
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																								V					V												
2	2013	Yukon Hybrid	Body	Lift Gate Module																																																								
2	2013	Yukon Hybrid	Body	Park Assist Module																																						V	V	V																	
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																																								
2	2013	Yukon Hybrid	Body	Passenger Presence System																																									V																
2	2013	Yukon Hybrid	Body	Radio																																																									
2	2013	Yukon Hybrid	Body	Navigation Radio																																																									
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																	V			V																					
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																								V					V												
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																								
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																								
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module	V			V																																																					
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module		V																																																							
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module										V																																															
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module										V																																															
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module	V			V																																																					
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module		V																																																							
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module										V																																															
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module										V																																															
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																					
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																							
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module										V																																															
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module	V			V																																																					
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module		V																																																							
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW														V																																											
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW														V																																											
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																									
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon XL	Body	Amplifier (Bose)																																																									
2	2013	Yukon XL	Body	Assist Step Controller																																																									
2	2013	Yukon XL	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																									
2	2013	Yukon XL	Body	Digital Radio Receiver																																																									
2	2013	Yukon XL	Body	Driver Door Switch																																																									
2	2013	Yukon XL	Body	HVAC Control Module Auto																												V	V																												
2	2013	Yukon XL	Body	HVAC Control Module Manual																													V																												
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																									
2	2013	Yukon XL	Body	Left Side Object Detection Module																																								V					V												
2	2013	Yukon XL	Body	Lift Gate Module																																																									
2	2013	Yukon XL	Body	Memory Seat Module																														V	V	V	V	V	V	V	V	V																			
2	2013	Yukon XL	Body	Park Assist Module																																						V	V	V																	
2	2013	Yukon XL	Body	Passenger Door Switch																																																									
2	2013	Yukon XL	Body	Passenger Presence System																																									V																

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2013	Yukon XL	Body	Radio																																																												
2	2013	Yukon XL	Body	Navigation Radio																																																												
2	2013	Yukon XL	Body	Rear Heated Seat Module																																		V				V																						
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																												
2	2013	Yukon XL	Body	Right Side Object Detection Module																																								V						V														
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
2	2013	Yukon XL	Body	Theft Deterrent Module																																																												
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																												
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2014	Sierra	Chassis	Electronic Brake Control Module																																																												
2	2014	Sierra	Chassis	Parking Brake Control Module																																																												
2	2014	Sierra	Chassis	Power Steering Control Module																																																												
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2014	Sierra	Body	Body Control Module																																																												
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2014	Sierra	Body	Passenger Presence Module																																																												
2	2014	Sierra	Body	Instrument Cluster																																																												
2	2014	Sierra	Body	Radio Control																																																												
2	2014	Sierra	Body	HVAC Control																																																												
2	2014	Sierra	Body	Radio																																																												
2	2014	Sierra	Body	Amplifier																																																												
2	2014	Sierra	Body	Media Disc Player																																																												
2	2014	Sierra	Body	Human Machine Interface Control Module																																																												
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																												
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
2	2014	Sierra	Body	Parking Assist Control Module																																																												
2	2014	Sierra	Body	Frontview Camera Module																																																												
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																												
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																												
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																												
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2014	Sierra HD	Chassis	Suspension Control Module																																																										
2	2014	Sierra HD	Body	Body Control Module																																																										
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Sierra HD	Body	Instrument Cluster																																																										
2	2014	Sierra HD	Body	Base Radio																																																										
2	2014	Sierra HD	Body	Navigation Radio																																																										
2	2014	Sierra HD	Body	Uplevel Radio																																																										
2	2014	Sierra HD	Body	Amplifier																																																										
2	2014	Sierra HD	Body	Rear Audio Control Module																																																										
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																										
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																										
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																										
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Sierra HD	Body	Seat Memory Control Module																																																										
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																										
2	2014	Sierra HD	Body	Parking Assist Control Module																																																										
2	2014	Sierra HD	Body	Theft Deterrent Module																																																										
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																										
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2014	Yukon	Chassis	Parking Brake Control Module																																																										
2	2014	Yukon	Chassis	Suspension Control Module																																																										
2	2014	Yukon	Body	Body Control Module																																																										
2	2014	Yukon	Body	Auxiliary Body Control Module																																																										
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Yukon	Body	Passenger Presence Module																																																										
2	2014	Yukon	Body	Instrument Cluster																																																										
2	2014	Yukon	Body	Base Radio																																																										
2	2014	Yukon	Body	Navigation Radio																																																										
2	2014	Yukon	Body	Uplevel Radio																																																										
2	2014	Yukon	Body	Amplifier																																																										
2	2014	Yukon	Body	Rear Audio Control Module																																																										
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																										
2	2014	Yukon	Body	Personal Audio Link Control Module																																																										
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Yukon	Body	Liftgate Control Module																																																											
2	2014	Yukon	Body	Seat Memory Control Module																																																											
2	2014	Yukon	Body	Rear Seat Heating Control Module																																																											
2	2014	Yukon	Body	Assist Step Control Module																																																											
2	2014	Yukon	Body	Right Side Object Detection Control Module																																																											
2	2014	Yukon	Body	Left Side Object Detection Control Module																																																											
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																											
2	2014	Yukon	Body	Parking Assist Control Module																																																											
2	2014	Yukon	Body	Theft Deterrent Module																																																											
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																											
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																											
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																											
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																											
2	2014	Yukon XL	Chassis	Suspension Control Module																																																											
2	2014	Yukon XL	Body	Body Control Module																																																											
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																											
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2014	Yukon XL	Body	Passenger Presence Module																																																											
2	2014	Yukon XL	Body	Instrument Cluster																																																											
2	2014	Yukon XL	Body	Base Radio																																																											
2	2014	Yukon XL	Body	Navigation Radio																																																											
2	2014	Yukon XL	Body	Uplevel Radio																																																											
2	2014	Yukon XL	Body	Amplifier																																																											
2	2014	Yukon XL	Body	Rear Audio Control Module																																																											
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																											
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																											
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																											
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																											
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																											
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																											
2	2014	Yukon XL	Body	Liftgate Control Module																																																											
2	2014	Yukon XL	Body	Seat Memory Control Module																																																											
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																											
2	2014	Yukon XL	Body	Assist Step Control Module																																																											
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																											
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																											
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																											
2	2014	Yukon XL	Body	Parking Assist Control Module																																																											
2	2014	Yukon XL	Body	Theft Deterrent Module																																																											
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Sierra	Chassis	Electronic Brake Control Module																																																										
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Sierra	Chassis	Power Steering Control Module																																																										
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Sierra	Chassis	Suspension Control Module																																																										
2	2015	Sierra	Body	Body Control Module																																																										
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Sierra	Body	Passenger Presence Module																																																										
2	2015	Sierra	Body	Instrument Cluster																																																										
2	2015	Sierra	Body	Radio Controls																																																										
2	2015	Sierra	Body	HVAC Controls																																																										
2	2015	Sierra	Body	Radio																																																										
2	2015	Sierra	Body	Amplifier																																																										
2	2015	Sierra	Body	Media Disc Player																																																										
2	2015	Sierra	Body	Human Machine Interface Control Module																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2015	Sierra	Body	Parking Assist Control Module																																																										
2	2015	Sierra	Body	Frontview Camera Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																										
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																										
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																										
2	2015	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Yukon	Chassis	Parking Brake Control Module																																																										
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																										
2	2015	Yukon	Chassis	Power Steering Control Module																																																										
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Yukon	Chassis	Suspension Control Module																																																										
2	2015	Yukon	Body	Body Control Module																																																										
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Yukon	Body	Passenger Presence Module																																																										
2	2015	Yukon	Body	Instrument Cluster																																																										
2	2015	Yukon	Body	Radio Controls																																																										
2	2015	Yukon	Body	HVAC Controls																																																										
2	2015	Yukon	Body	Radio																																																										
2	2015	Yukon	Body	Amplifier																																																										
2	2015	Yukon	Body	Media Disc Player																																																										
2	2015	Yukon	Body	Human Machine Interface Control Module																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Yukon	Body	HVAC Control Module																																																										
2	2015	Yukon	Body	Liftgate Control Module																																																										
2	2015	Yukon	Body	Keyless Entry Control Module																																																										
2	2015	Yukon	Body	Assist Step Control Module																																																										
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																										
2	2015	Yukon	Body	Parking Assist Control Module																																																										
2	2015	Yukon	Body	Frontview Camera Module																																																										
2	2015	Yukon	Body	Steering Column Lock Control Module																																																										
2	2015	Yukon	Body	Battery Energy Control Module																																																										
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
2	2015	Yukon XL	Chassis	Power Steering Control Module																																																										
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Yukon XL	Chassis	Suspension Control Module																																																										
2	2015	Yukon XL	Body	Body Control Module																																																										
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Yukon XL	Body	Passenger Presence Module																																																										
2	2015	Yukon XL	Body	Instrument Cluster																																																										
2	2015	Yukon XL	Body	Radio Controls																																																										
2	2015	Yukon XL	Body	HVAC Controls																																																										
2	2015	Yukon XL	Body	Radio																																																										
2	2015	Yukon XL	Body	Amplifier																																																										
2	2015	Yukon XL	Body	Media Disc Player																																																										
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Yukon XL	Body	HVAC Control Module																																																										
2	2015	Yukon XL	Body	Liftgate Control Module																																																										
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
2	2015	Yukon XL	Body	Assist Step Control Module																																																										
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
2	2015	Yukon XL	Body	Parking Assist Control Module																																																										
2	2015	Yukon XL	Body	Frontview Camera Module																																																										
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2016	Sierra	Chassis	Electronic Brake Control Module																																																										
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
2	2016	Sierra	Chassis	Parking Brake Control Module																																																										
2	2016	Sierra	Chassis	Power Steering Control Module																																																										
2	2016	Sierra	Chassis	Power Steering Control Module																																																										
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2016	Sierra	Chassis	Suspension Control Module																																																										
2	2016	Sierra	Body	Body Control Module																																																										
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2016	Sierra	Body	Passenger Presence Module																																																										
2	2016	Sierra	Body	Instrument Cluster																																																										
2	2016	Sierra	Body	Radio Controls																																																										
2	2016	Sierra	Body	HVAC Controls																																																										
2	2016	Sierra	Body	Radio (IO3)																																																										
2	2016	Sierra	Body	Radio (IOB)																																																										
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
2	2016	Sierra	Body	Amplifier																																																										
2	2016	Sierra	Body	Media Disc Player																																																										
2	2016	Sierra	Body	Human Machine Interface Control Module																																																										
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																										
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																										
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																										
2	2016	Sierra	Body	Parking Assist Control Module																																																										
2	2016	Sierra	Body	Frontview Camera Module																																																										
2	2016	Sierra	Body	Frontview Camera Module																																																										
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2016	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
2	2016	Yukon	Chassis	Parking Brake Control Module																																																										
2	2016	Yukon	Chassis	Power Steering Control Module																																																										
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2016	Yukon	Chassis	Suspension Control Module																																																										
2	2016	Yukon	Body	Body Control Module																																																										
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2016	Yukon	Body	Passenger Presence Module																																																										
2	2016	Yukon	Body	Instrument Cluster																																																										
2	2016	Yukon	Body	Radio Controls																																																										
2	2016	Yukon	Body	HVAC Controls																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
2	2016	Yukon	Body	Radio																																																											
2	2016	Yukon	Body	Amplifier																																																											
2	2016	Yukon	Body	Media Disc Player																																																											
2	2016	Yukon	Body	Human Machine Interface Control Module																																																											
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																											
2	2016	Yukon	Body	HVAC Control Module																																																											
2	2016	Yukon	Body	Liftgate Control Module																																																											
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																											
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																											
2	2016	Yukon	Body	Keyless Entry Control Module																																																											
2	2016	Yukon	Body	Assist Step Control Module																																																											
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																											
2	2016	Yukon	Body	Parking Assist Control Module																																																											
2	2016	Yukon	Body	Frontview Camera Module																																																											
2	2016	Yukon	Body	Steering Column Lock Control Module																																																											
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																											
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																											
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																											
2	2016	Yukon XL	Chassis	Power Steering Control Module																																																											
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2016	Yukon XL	Chassis	Suspension Control Module																																																											
2	2016	Yukon XL	Body	Body Control Module																																																											
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2016	Yukon XL	Body	Passenger Presence Module																																																											
2	2016	Yukon XL	Body	Instrument Cluster																																																											
2	2016	Yukon XL	Body	Radio Controls																																																											
2	2016	Yukon XL	Body	HVAC Controls																																																											
2	2016	Yukon XL	Body	Radio																																																											
2	2016	Yukon XL	Body	Amplifier																																																											
2	2016	Yukon XL	Body	Media Disc Player																																																											
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																											
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																											
2	2016	Yukon XL	Body	HVAC Control Module																																																											
2	2016	Yukon XL	Body	Liftgate Control Module																																																											
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																											
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																											
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																											
2	2016	Yukon XL	Body	Assist Step Control Module																																																											
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																											
2	2016	Yukon XL	Body	Parking Assist Control Module																																																											
2	2016	Yukon XL	Body	Frontview Camera Module																																																											
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																											
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																	
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V			V																																																							
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
5	2011	ALL	Chassis	Electronic Brake Control Module																																																												
5	2011	ALL	Body	Body Control Module																																																												
5	2011	ALL	Body	Digital Radio Receiver																																																												
5	2011	ALL	Body	Generator Battery Control Module																																																												
5	2011	ALL	Body	Instrument Panel Cluster																																																												
5	2011	ALL	Body	Passenger Presence System																																																												
5	2011	ALL	Body	Personal Audio Link Module																																																												
5	2011	ALL	Body	Base Radio																																																												
5	2011	ALL	Body	Uplevel Radio																																																												
5	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
5	2011	ALL	Body	Theft Deterrent Module																																																												
5	2011	ALL	Body	Vehicle Comm. Interface Module																																																												
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																		
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																		
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V			V																																																								
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
5	2012	ALL	Chassis	Electronic Brake Control Module																																																												
5	2012	ALL	Body	Body Control Module																																																												
5	2012	ALL	Body	Digital Radio Receiver																																																												
5	2012	ALL	Body	Generator Battery Control Module																																																												
5	2012	ALL	Body	Instrument Panel Cluster																																																												
5	2012	ALL	Body	Passenger Presence System																																																												
5	2012	ALL	Body	Personal Audio Link Module																																																												
5	2012	ALL	Body	Base Radio																																																												
5	2012	ALL	Body	Uplevel Radio																																																												
5	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
5	2012	ALL	Body	Theft Deterrent Module																																																												
5	2012	ALL	Body	Vehicle Comm. Interface Module																																																												
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
5	2015	Canyon	Powertrain	Chassis Control Module																																																												
5	2015	Canyon	Powertrain	Transfer Case Control Module																																																												
5	2015	Canyon	Chassis	Electronic Brake Control Module																																																												
5	2015	Canyon	Chassis	Power Steering Control Module																																																												
5	2015	Canyon	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
5	2015	Canyon	Body	Passenger Presence Module																																																											
5	2015	Canyon	Body	Radio																																																										
5	2015	Canyon	Body	Amplifier																																																										
5	2015	Canyon	Body	Human Machine Interface Control Module																																																											
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																																											
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																											
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																											
5	2015	Canyon	Body	Parking Assist Control Module																																																											
5	2015	Canyon	Body	Frontview Camera Module																																																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																											
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
5	2016	Canyon	Powertrain	Transfer Case Control Module																																																											
5	2016	Canyon	Chassis	Electronic Brake Control Module																																																											
5	2016	Canyon	Chassis	Power Steering Control Module																																																											
5	2016	Canyon	Body	Body Control Module																																																											
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
5	2016	Canyon	Body	Passenger Presence Module																																																											
5	2016	Canyon	Body	Trailer Interface Control Module																																																											
5	2016	Canyon	Body	Radio																																																											
5	2016	Canyon	Body	Amplifier																																																											
5	2016	Canyon	Body	Human Machine Interface Control Module																																																											
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																																											
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																											
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																											
5	2016	Canyon	Body	Frontview Camera Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module				V					V																																																	
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module				V					V																																																	
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V			V																																																							
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
6	2011	ALL	Chassis	Electronic Brake Control Module																																																											
6	2011	ALL	Body	Body Control Module																																																											
6	2011	ALL	Body	Digital Radio Receiver																																																											
6	2011	ALL	Body	Generator Battery Control Module																																																											
6	2011	ALL	Body	Instrument Panel Cluster																																																											
6	2011	ALL	Body	Passenger Presence System																																																											
6	2011	ALL	Body	Personal Audio Link Module																																																											
6	2011	ALL	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
6	2011	ALL	Body	Uplevel Radio																																																										
6	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
6	2011	ALL	Body	Theft Deterrent Module																																																										
6	2011	ALL	Body	Vehicle Comm. Interface Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module				V						V																																																
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module				V						V																																																
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module	V			V																																																						
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
6	2012	ALL	Chassis	Electronic Brake Control Module																																																										
6	2012	ALL	Body	Body Control Module																																																										
6	2012	ALL	Body	Digital Radio Receiver																																																										
6	2012	ALL	Body	Generator Battery Control Module																																																										
6	2012	ALL	Body	Instrument Panel Cluster																																																										
6	2012	ALL	Body	Passenger Presence System																																																										
6	2012	ALL	Body	Personal Audio Link Module																																																										
6	2012	ALL	Body	Base Radio																																																										
6	2012	ALL	Body	Uplevel Radio																																																										
6	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
6	2012	ALL	Body	Theft Deterrent Module																																																										
6	2012	ALL	Body	Vehicle Comm. Interface Module																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
6	2015	Canyon	Powertrain	Chassis Control Module																																																										
6	2015	Canyon	Powertrain	Transfer Case Control Module																																																										
6	2015	Canyon	Chassis	Electronic Brake Control Module																																																										
6	2015	Canyon	Chassis	Power Steering Control Module																																																										
6	2015	Canyon	Body	Body Control Module																																																										
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
6	2015	Canyon	Body	Passenger Presence Module																																																										
6	2015	Canyon	Body	Radio																																																										
6	2015	Canyon	Body	Amplifier																																																										
6	2015	Canyon	Body	Human Machine Interface Control Module																																																										
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																																										
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
6	2015	Canyon	Body	Parking Assist Control Module																																																										
6	2015	Canyon	Body	Frontview Camera Module																																																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																											
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
6	2016	Canyon	Powertrain	Transfer Case Control Module																																																											
6	2016	Canyon	Chassis	Electronic Brake Control Module																																																											
6	2016	Canyon	Chassis	Power Steering Control Module																																																											
6	2016	Canyon	Body	Body Control Module																																																											
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
6	2016	Canyon	Body	Passenger Presence Module																																																											
6	2016	Canyon	Body	Trailer Interface Control Module																																																											
6	2016	Canyon	Body	Radio																																																										
6	2016	Canyon	Body	Amplifier																																																										
6	2016	Canyon	Body	Human Machine Interface Control Module																																																										
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																																										
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
6	2016	Canyon	Body	Frontview Camera Module																																																										
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																								
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																								
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																											
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2011	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
7	2011	Express/Savana	Body	Digital Radio Receiver																																																										
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
7	2011	Express/Savana	Body	Passenger Presence System																																										V	V																
7	2011	Express/Savana	Body	Radio																																																										
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
7	2011	Express/Savana	Body	Rollover Sensor																																																										
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																									V									V							
7	2011	Express/Savana	Body	Theft Deterrent Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																								
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																							
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																									
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																									
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																													
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2011	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																	
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V																	
7	2011	Express Access/Savana Pro	Body	Radio																																																												
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																												
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V							
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																								
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																								
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																										
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																								
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																								
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																										
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																								
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																										
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																										
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																														
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
7	2012	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																	
7	2012	Express/Savana	Body	Digital Radio Receiver																																																												
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																												
7	2012	Express/Savana	Body	Passenger Presence System																																									V	V																	
7	2012	Express/Savana	Body	Radio																																																												
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
7	2012	Express/Savana	Body	Rollover Sensor																																																												
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																									V									V							
7	2012	Express/Savana	Body	Theft Deterrent Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																								
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																								
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																								
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																												
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2012	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																											V	V														
7	2012	Express Access/Savana Pro	Body	Radio																																																										
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																											V									V						
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																								
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																								
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																												
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2013	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
7	2013	Express/Savana	Body	Digital Radio Receiver																																																										
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
7	2013	Express/Savana	Body	Passenger Presence System																																											V	V														
7	2013	Express/Savana	Body	Radio																																																										
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
7	2013	Express/Savana	Body	Rollover Sensor																																																										
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																											V									V						
7	2013	Express/Savana	Body	Theft Deterrent Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module	V			V																																																						
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																								

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module		V																																																								
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																												
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
7	2013	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																																
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																											
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																											
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																							V	V	V																		
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V																
7	2013	Express Access/Savana Pro	Body	Radio																																																											
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																											
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V										V						
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																											
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																											
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																											
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																											
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																											
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																											
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																											
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
7	2014	Savana	Chassis	Electronic Brake Control Module																																																											
7	2014	Savana	Body	Body Control Module																																																											
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
7	2014	Savana	Body	Passenger Presence Module																																																											
7	2014	Savana	Body	Rollover Sensor Module																																																											
7	2014	Savana	Body	Instrument Cluster																																																											
7	2014	Savana	Body	Chime Alarm Control Module																																																											
7	2014	Savana	Body	Base Radio																																																											
7	2014	Savana	Body	Navigation Radio																																																											
7	2014	Savana	Body	Uplevel Radio																																																											
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																											
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
7	2014	Savana	Body	Auxiliary Heater Control Module																																																										
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2014	Savana	Body	Parking Assist Control Module																																																										
7	2014	Savana	Body	Theft Deterrent Module																																																										
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2015	Savana	Chassis	Electronic Brake Control Module																																																										
7	2015	Savana	Body	Body Control Module																																																										
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2015	Savana	Body	Rollover Sensor Module																																																										
7	2015	Savana	Body	Instrument Cluster																																																										
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
7	2015	Savana	Body	Auxiliary Heater Control Module																																																										
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2015	Savana	Body	Parking Assist Control Module																																																										
7	2015	Savana	Body	Theft Deterrent Module																																																										
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2016	Savana	Chassis	Electronic Brake Control Module																																																										
7	2016	Savana	Body	Body Control Module																																																										
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2016	Savana	Body	Instrument Cluster																																																										
7	2016	Savana	Body	Chime Alarm Control Module																																																										
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
7	2016	Savana	Body	Auxiliary Heater Control Module																																																										
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2016	Savana	Body	Parking Assist Control Module																																																										
7	2016	Savana	Body	Theft Deterrent Module																																																										
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																						
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																								
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																						
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																						

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																												
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
8	2011	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
8	2011	Express/Savana	Body	Digital Radio Receiver																																																											
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																											
8	2011	Express/Savana	Body	Passenger Presence System																																										V	V															
8	2011	Express/Savana	Body	Radio																																																											
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
8	2011	Express/Savana	Body	Rollover Sensor																																																											
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																									V									V							
8	2011	Express/Savana	Body	Theft Deterrent Module																																																											
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																							
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																									
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																												
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
8	2011	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																											
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V															
8	2011	Express Access/Savana Pro	Body	Radio																																																											
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																											
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V									V							
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																							
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																									
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																							
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																							
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																									
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																							
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																									
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																												
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
8	2012	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
8	2012	Express/Savana	Body	Digital Radio Receiver																																																											
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																											
8	2012	Express/Savana	Body	Passenger Presence System																																									V	V															
8	2012	Express/Savana	Body	Radio																																																											
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																											

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
8	2012	Express/Savana	Body	Rollover Sensor																																																									
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
8	2012	Express/Savana	Body	Theft Deterrent Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																					
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																							
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																					
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																					
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																							
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																					
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																							
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																											
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2012	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																														
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																									
8	2012	Express Access/Savana Pro	Body	Radio																																																									
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																									
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																					
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																							
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																					
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																					
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																							
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																					
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																							
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES														V																																											
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2013	Express/Savana	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																														
8	2013	Express/Savana	Body	Digital Radio Receiver																																																									
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																									
8	2013	Express/Savana	Body	Navigation Radio																																																									
8	2013	Express/Savana	Body	Park Assist Module																																							V	V	V																
8	2013	Express/Savana	Body	Passenger Presence System																																										V	V														
8	2013	Express/Savana	Body	Radio																																																									
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
8	2013	Express/Savana	Body	Rollover Sensor																																																									
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																										V											V				
8	2013	Express/Savana	Body	Theft Deterrent Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module	V			V																																																					
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module		V																																																							
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module	V			V																																																					
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module	V			V																																																					

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module		V																																																								
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module	V			V																																																						
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module		V																																																								
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES														V																																											
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
8	2013	Express Access/Savana Pro	Body	Body Control Module															V	V	V	V	V	V	V		V	V			V																															
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																											
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																											
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																							V	V	V																		
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																									V	V																
8	2013	Express Access/Savana Pro	Body	Radio																																																											
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																											
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																									V										V						
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																												
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
8	2014	Savana	Chassis	Electronic Brake Control Module																																																												
8	2014	Savana	Body	Body Control Module																																																												
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
8	2014	Savana	Body	Passenger Presence Module																																																												
8	2014	Savana	Body	Rollover Sensor Module																																																												
8	2014	Savana	Body	Instrument Cluster																																																												
8	2014	Savana	Body	Chime Alarm Control Module																																																												
8	2014	Savana	Body	Base Radio																																																												
8	2014	Savana	Body	Navigation Radio																																																												
8	2014	Savana	Body	Uplevel Radio																																																												
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																												
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																												
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																												
8	2014	Savana	Body	Auxiliary Heater Control Module																																																												
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																												
8	2014	Savana	Body	Parking Assist Control Module																																																												
8	2014	Savana	Body	Theft Deterrent Module																																																												
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
8	2015	Savana	Chassis	Electronic Brake Control Module																																																										
8	2015	Savana	Body	Body Control Module																																																										
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
8	2015	Savana	Body	Rollover Sensor Module																																																										
8	2015	Savana	Body	Instrument Cluster																																																										
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
8	2015	Savana	Body	Auxiliary Heater Control Module																																																										
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
8	2015	Savana	Body	Parking Assist Control Module																																																										
8	2015	Savana	Body	Theft Deterrent Module																																																										
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
8	2016	Savana	Chassis	Electronic Brake Control Module																																																										
8	2016	Savana	Body	Body Control Module																																																										
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
8	2016	Savana	Body	Instrument Cluster																																																										
8	2016	Savana	Body	Chime Alarm Control Module																																																										
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
8	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
8	2016	Savana	Body	Auxiliary Heater Control Module																																																										
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
8	2016	Savana	Body	Parking Assist Control Module																																																										
8	2016	Savana	Body	Theft Deterrent Module																																																										
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																										
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																										
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module											V																																														
ALL	2004	ALL	Chassis	ABS																																																									
ALL	2004	ALL	Chassis	Air Suspension																																																									
ALL	2004	ALL	Body	Amplifier (Bose)																																																									
ALL	2004	ALL	Body	Body Control Module																																																									
ALL	2004	ALL	Body	Digital Radio Receiver																																																									
ALL	2004	ALL	Body	Driver Door Module																																																									
ALL	2004	ALL	Body	Driver Seat Module																																																									
ALL	2004	ALL	Body	Heating and Air Conditioning																																																									
ALL	2004	ALL	Body	Instrument Panel Cluster																																																									
ALL	2004	ALL	Body	OnStar																																																									
ALL	2004	ALL	Body	Passenger Door Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
ALL	2004	ALL	Body	Uplevel Radio																																																										
ALL	2004	ALL	Body	Navigation Radio																																																										
ALL	2004	ALL	Body	Rear Seat Audio																																																										
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																										
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																										
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module											V																																															
ALL	2005	ALL	Chassis	ABS																																																										
ALL	2005	ALL	Chassis	Air Suspension																																																										
ALL	2005	ALL	Body	Body Control Module																																																										
ALL	2005	ALL	Body	Digital Radio Receiver																																																										
ALL	2005	ALL	Body	Driver Door Module (SUV)																																																										
ALL	2005	ALL	Body	Driver Door Module (SUT)																																																										
ALL	2005	ALL	Body	Driver Seat Module																																																										
ALL	2005	ALL	Body	Heating and Air Conditioning																																																										
ALL	2005	ALL	Body	Instrument Panel Cluster																																																										
ALL	2005	ALL	Body	Passenger Door Module																																																										
ALL	2005	ALL	Body	Uplevel Radio																																																										
ALL	2005	ALL	Body	Navigation Radio																																																										
ALL	2005	ALL	Body	Rear Seat Audio																																																										
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																										
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																										
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module											V																																															
ALL	2006	H2	Chassis	ABS																																																										
ALL	2006	H2	Chassis	Air Suspension																																																										
ALL	2006	H2	Body	Body Control Module																																																										
ALL	2006	H2	Body	Digital Radio Receiver																																																										
ALL	2006	H2	Body	Driver Door Module (SUV)																																																										
ALL	2006	H2	Body	Driver Door Module (SUT)																																																										
ALL	2006	H2	Body	Driver Seat Module																																																										
ALL	2006	H2	Body	Heating and Air Conditioning																																																										
ALL	2006	H2	Body	Instrument Panel Cluster																																																										
ALL	2006	H2	Body	Passenger Door Module																																																										
ALL	2006	H2	Body	Uplevel Radio																																																										
ALL	2006	H2	Body	Navigation Radio																																																										
ALL	2006	H2	Body	Rear Seat Audio																																																										
ALL	2006	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	H3	Powertrain	Engine Control Module																																																										
ALL	2006	H3	Powertrain	Transmission Control Module																																																										
ALL	2006	H3	Powertrain	Transfer Case Control Module											V																																															
ALL	2006	H3	Chassis	Antilock Brake System																																																										
ALL	2006	H3	Body	Body Control Module																																																										
ALL	2006	H3	Body	Digital Radio Receiver																																																										
ALL	2006	H3	Body	Instrument Panel Cluster																																																										
ALL	2006	H3	Body	Uplevel Radio																																																							V			
ALL	2006	H3	Body	Navigation Radio																																																										
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																										
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																										
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module											V																																															

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
ALL	2007	H2	Chassis	ABS																																																									
ALL	2007	H2	Chassis	Air Suspension																																																									
ALL	2007	H2	Body	Amplifier (Bose)																																																									
ALL	2007	H2	Body	Body Control Module																																																									
ALL	2007	H2	Body	Digital Radio Receiver																																																									
ALL	2007	H2	Body	Driver Door Module (SUV)																																																									
ALL	2007	H2	Body	Driver Door Module (SUT)																																																									
ALL	2007	H2	Body	Driver Seat Module																																																									
ALL	2007	H2	Body	HVAC Control Module																																																									
ALL	2007	H2	Body	Instrument Panel Cluster																																																									
ALL	2007	H2	Body	Passenger Door Module																																																									
ALL	2007	H2	Body	Uplevel Radio																																																									
ALL	2007	H2	Body	Navigation Radio																																																									
ALL	2007	H2	Body	Rear Seat Audio																																																									
ALL	2007	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																																									
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module									V	V																																															
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																									
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module											V																																														
ALL	2007	H3	Chassis	EBCM																																																									
ALL	2007	H3	Body	Body Control Module (5GT)																																																									
ALL	2007	H3	Body	Body Control Module (ADM)																																																									
ALL	2007	H3	Body	Digital Radio Receiver																																																									
ALL	2007	H3	Body	Generator Battery Control Module																																																									
ALL	2007	H3	Body	Instrument Panel Cluster																																																									
ALL	2007	H3	Body	Personal Audio Link Module																																																									
ALL	2007	H3	Body	Uplevel Radio																																																						V		
ALL	2007	H3	Body	Navigation Radio																																																									
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																																									
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module	V			V																																																					
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module		V																																																							
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module											V																																														
ALL	2008	H2	Chassis	Air SCM																																																									
ALL	2008	H2	Chassis	EBCM																																																									
ALL	2008	H2	Body	Amplifier (Bose)																																																									
ALL	2008	H2	Body	Body Control Module														V	V	V	V	V	V	V	V	V	V			V																															
ALL	2008	H2	Body	Digital Radio Receiver																																																									
ALL	2008	H2	Body	Driver Door Switch																																																									
ALL	2008	H2	Body	HVAC Control Module																												V	V																												
ALL	2008	H2	Body	Instrument Panel Cluster																																																									
ALL	2008	H2	Body	Memory Seat Module																															V	V	V	V	V	V	V	V																			
ALL	2008	H2	Body	Passenger Door Switch																																																									
ALL	2008	H2	Body	Radio																																																									
ALL	2008	H2	Body	Rear Heated Seat Module																																V				V																					
ALL	2008	H2	Body	Rear HVAC/RSA																																																									
ALL	2008	H2	Body	Rollover Sensor																																																									
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																								V									V								
ALL	2008	H2	Body	Theft Deterrent Module																																																									
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)										V																																														
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)										V																																														
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																								
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module											V																																													
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module	V			V																																																				
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																								
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module											V																																													
ALL	2008	H3	Chassis	EBCM																																																								
ALL	2008	H3	Body	Body Control Module (5GT)																																																								
ALL	2008	H3	Body	Body Control Module (ADM)																																																								
ALL	2008	H3	Body	Digital Radio Receiver																																																								
ALL	2008	H3	Body	Generator Battery Control Module																																																								
ALL	2008	H3	Body	Instrument Panel Cluster																																																								
ALL	2008	H3	Body	Personal Audio Link Module																																																								
ALL	2008	H3	Body	Uplevel Radio																																																					V		
ALL	2008	H3	Body	Navigation Radio																																																								
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																																								
ALL	2008	H3	Body	Theft Deterrent Module																																																								
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																																								
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module	V			V																																																				
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																								
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module		V																																																						
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module											V																																													
ALL	2009	H2	Chassis	Air SCM																																																								
ALL	2009	H2	Chassis	EBCM																																																								
ALL	2009	H2	Body	Amplifier (Bose)																																																								
ALL	2009	H2	Body	Body Control Module															V	V	V	V	V		V		V	V			V																														
ALL	2009	H2	Body	Digital Radio Receiver																																																								
ALL	2009	H2	Body	Driver Door Switch																																																								
ALL	2009	H2	Body	HVAC Control Module																												V	V																												
ALL	2009	H2	Body	Instrument Panel Cluster																																																								
ALL	2009	H2	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																				
ALL	2009	H2	Body	Passenger Door Switch																																																								
ALL	2009	H2	Body	Radio																																																								
ALL	2009	H2	Body	Rear Heated Seat Module																																	V				V																				
ALL	2009	H2	Body	Rear HVAC/RSA																																																								
ALL	2009	H2	Body	Rollover Sensor																																																								
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																									V									V						
ALL	2009	H2	Body	Theft Deterrent Module																																																								
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																								
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																								
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)										V																																														
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)										V																																														
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																								
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																								
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)											V																																													
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)											V																																													
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)	V			V																																																				
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)	V			V																																																				
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																								
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)											V																																															
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)											V																																															
ALL	2009	H3	Chassis	EBCM																																																										
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																																										
ALL	2009	H3	Body	Body Control Module (ADM)																																																										
ALL	2009	H3	Body	Digital Radio Receiver																																																										
ALL	2009	H3	Body	Generator Battery Control Module																																																										
ALL	2009	H3	Body	Instrument Panel Cluster																																																										
ALL	2009	H3	Body	Personal Audio Link Module																																																										
ALL	2009	H3	Body	Uplevel Radio																																																								V		
ALL	2009	H3	Body	Navigation Radio																																																										
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	H3	Body	Theft Deterrent Module																																																										
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module	V			V																																																							
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																											
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module		V																																																									
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module											V																																																
ALL	2010	H2	Chassis	Air SCM																																																											
ALL	2010	H2	Chassis	EBCM																																																										
ALL	2010	H2	Body	Amplifier (Bose)																																																										
ALL	2010	H2	Body	Body Control Module															V	V	V	V	V		V		V	V			V																																
ALL	2010	H2	Body	Digital Radio Receiver																																																										
ALL	2010	H2	Body	Driver Door Switch																																																										
ALL	2010	H2	Body	HVAC Control Module																												V	V																														
ALL	2010	H2	Body	Instrument Panel Cluster																																																										
ALL	2010	H2	Body	Memory Seat Module																														V	V	V	V	V	V	V	V																					
ALL	2010	H2	Body	Passenger Door Switch																																																										
ALL	2010	H2	Body	Personal Audio Link Module																																																										
ALL	2010	H2	Body	Radio																																																										
ALL	2010	H2	Body	Rear Heated Seat Module																																	V				V																					
ALL	2010	H2	Body	Rear HVAC/RSA																																																										
ALL	2010	H2	Body	Rollover Sensor																																																										
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																										V									V					
ALL	2010	H2	Body	Theft Deterrent Module																																																										
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module										V																																																
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)											V																																															
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)											V																																															
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module	V			V																																																						
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)											V																																															
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)											V																																															
ALL	2010	H3	Chassis	EBCM																																																										
ALL	2010	H3	Body	Body Control Module																																																										
ALL	2010	H3	Body	Digital Radio Receiver																																																										
ALL	2010	H3	Body	Generator Battery Control Module																																																										
ALL	2010	H3	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	HO2S Heater learn	Solenoid Data	Fast Learn Adapt. Process	Idle learn	Fuel Data	VES Data	Air Quality Sensitivity Level	Tuner Calibration	CMP Data	I/M Data	Transfer Case Data	Reset Clutch Overtemp Counter	Steering Angle Sensor Centering	Yaw Rate Sensor Recalibration	Body Rear End	Brake Pedal	Charging Info.	Doors	Exterior Lighting	Personalization	Power Mode	Remote Start Disable History Data	Theft Data	Wiper/Washer	Adaptive Forward Lighting Data	Dynamic Headlamp Leveling Data	Chassis Data	HVAC Sensors	A/C Permission	Afterblow Option	Seat 1 Inputs	Seat 1 Outputs	Seat 1 Info.	Seat 1 HVC Data	Seat 2 Inputs	Seat 2 Outputs	Seat 2 Info.	Seat 2 HVC Data	Column Info.	System Data	History Data	Battery Data	Key Identification	Preload Passenger Presence System	General Information	Sensor Information	Data Recorder	Setup New PIDM	HVAC	Memory Seat Module	Radio	System Contiguration	IPC Setup	Radio Setup	PSCM Calibration Procedure	Actuator Removal Procedure
ALL	2010	H3	Body	Personal Audio Link Module																																																										
ALL	2010	H3	Body	Uplevel Radio																																																									V		
ALL	2010	H3	Body	Navigation Radio																																																										
ALL	2010	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	H3	Body	Theft Deterrent Module																																																										
ALL	2010	H3	Body	Vehicle Comm. Interface Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																											
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																											
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																											
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																											
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																											
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
C	2004	ALL	Chassis	ESC																																																										
C	2004	ALL	Chassis	Rear Wheel Steering																																																											
C	2004	ALL	Chassis	Tire Pressure Monitor																																																											
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2004	ALL	Chassis	VSES																																																										
C	2004	ALL	Body	Amplifier (Bose)																																																											
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2004	ALL	Body	Instrument Panel Cluster																																																											
C	2004	ALL	Body	OnStar																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2004	ALL	Body	Passenger Door Module																																																													
C	2004	ALL	Body	Passenger Presence System																																																													
C	2004	ALL	Body	Radio Base																																																												
C	2004	ALL	Body	Radio Uplevel																																																												
C	2004	ALL	Body	Radio Navigation																																																												
C	2004	ALL	Body	Rear Aux. Climate Module																																																												
C	2004	ALL	Body	Rear HVAC																																																												
C	2004	ALL	Body	Rear Seat Audio																																																												
C	2004	ALL	Body	Rear Seat Entertainment																																																												
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2004	ALL	Body	Vehicle Theft Deterrent																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																												
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
C	2005	ALL	Chassis	ESC																																																												
C	2005	ALL	Chassis	Rear Wheel Steering																																																												
C	2005	ALL	Chassis	Tire Pressure Monitor																																																												
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2005	ALL	Chassis	VSES																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2005	ALL	Body	Amplifier (Bose)																																																														
C	2005	ALL	Body	Body Control Module																																																														
C	2005	ALL	Body	CD Changer																																																														
C	2005	ALL	Body	Chime																																																													
C	2005	ALL	Body	Disc Player and Video Display																																																														
C	2005	ALL	Body	Driver Door Module																																																														
C	2005	ALL	Body	Driver Seat Module																																																														
C	2005	ALL	Body	Generator Battery Control Module																																																														
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																														
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																														
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																														
C	2005	ALL	Body	Instrument Panel Cluster																																																														
C	2005	ALL	Body	Passenger Door Module																																																														
C	2005	ALL	Body	Passenger Presence System																																																														
C	2005	ALL	Body	Base Radio																																																														
C	2005	ALL	Body	Uplevel Radio																																																														
C	2005	ALL	Body	Navigation Radio																																																														
C	2005	ALL	Body	Rear Aux. Climate Module																																																														
C	2005	ALL	Body	Rear HVAC																																																														
C	2005	ALL	Body	Rear Seat Audio																																																														
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																														
C	2005	ALL	Body	Vehicle Theft Deterrent																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																														
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																														
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																														
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																												
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																													
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
C	2006	ALL	Chassis	ESC																																																												
C	2006	ALL	Chassis	Tire Pressure Monitor																																																												
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2006	ALL	Chassis	VSES																																																												
C	2006	ALL	Body	Amplifier (Bose)																																																												
C	2006	ALL	Body	Body Control Module																																																												
C	2006	ALL	Body	CD Changer																																																												
C	2006	ALL	Body	Chime																																																												
C	2006	ALL	Body	Disc Player and Video Display																																																												
C	2006	ALL	Body	Driver Door Module																																																												
C	2006	ALL	Body	Driver Seat Module																																																												
C	2006	ALL	Body	Generator Battery Control Module																																																												
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																												
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
C	2006	ALL	Body	Instrument Panel Cluster																																																												
C	2006	ALL	Body	Passenger Door Module																																																												
C	2006	ALL	Body	Passenger Presence System																																																												
C	2006	ALL	Body	Base Radio																																																												
C	2006	ALL	Body	Uplevel Radio																																																												
C	2006	ALL	Body	Navigation Radio																																																												
C	2006	ALL	Body	Rear Aux. Climate Module																																																												
C	2006	ALL	Body	Rear HVAC																																																												
C	2006	ALL	Body	Rear Seat Audio																																																												
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2006	ALL	Body	Vehicle Theft Deterrent																																																												
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Sierra	Chassis	Electronic Suspension Control																																																												
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2007	Sierra	Body	Amplifier (Bose)																																																												
C	2007	Sierra	Body	Body Control Module																																																												
C	2007	Sierra	Body	Body Control Module (aux.)																																																												
C	2007	Sierra	Body	Digital Radio Receiver																																																												
C	2007	Sierra	Body	Driver Door Switch																																																												
C	2007	Sierra	Body	HVAC Control Module Auto																																																												
C	2007	Sierra	Body	HVAC Control Module Manual																																																												
C	2007	Sierra	Body	Instrument Panel Cluster																																																												
C	2007	Sierra	Body	Memory Seat Module																																																												
C	2007	Sierra	Body	Park Assist Module																																																												
C	2007	Sierra	Body	Passenger Door Switch																																																												
C	2007	Sierra	Body	Passenger Presence System																																																												
C	2007	Sierra	Body	Radio																																																											
C	2007	Sierra	Body	Rear Heated Seat Module																																																												
C	2007	Sierra	Body	Rear HVAC/RSA																																																												
C	2007	Sierra	Body	Rollover Sensor																																																												
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2007	Sierra	Body	Theft Deterrent Module																																																												
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Yukon	Chassis	Electronic Suspension Control																																																												
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																												
C	2007	Yukon	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2007	Yukon	Body	Assist Step Controller																																																											
C	2007	Yukon	Body	Body Control Module																																																											
C	2007	Yukon	Body	Body Control Module (aux.)																																																											
C	2007	Yukon	Body	Digital Radio Receiver																																																											
C	2007	Yukon	Body	Driver Door Switch																																																											
C	2007	Yukon	Body	HVAC Control Module Auto																																																											
C	2007	Yukon	Body	HVAC Control Module Manual																																																											
C	2007	Yukon	Body	Instrument Panel Cluster																																																											
C	2007	Yukon	Body	Lift Gate Module																									V	V																																	
C	2007	Yukon	Body	Memory Seat Module																																																											
C	2007	Yukon	Body	Park Assist Module																																																											
C	2007	Yukon	Body	Passenger Door Switch																																																											
C	2007	Yukon	Body	Passenger Presence System																																																											
C	2007	Yukon	Body	Radio																																																											
C	2007	Yukon	Body	Rear Heated Seat Module																																																											
C	2007	Yukon	Body	Rear HVAC/RSA																																																											
C	2007	Yukon	Body	Rollover Sensor																																																											
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																																											
C	2007	Yukon	Body	Theft Deterrent Module																																																											
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																											
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																											
C	2007	Yukon XL	Body	Amplifier (Bose)																																																											
C	2007	Yukon XL	Body	Assist Step Controller																																																											
C	2007	Yukon XL	Body	Body Control Module																																																											
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																											
C	2007	Yukon XL	Body	Digital Radio Receiver																																																											
C	2007	Yukon XL	Body	Driver Door Switch																																																											
C	2007	Yukon XL	Body	HVAC Control Module Auto																																																											
C	2007	Yukon XL	Body	HVAC Control Module Manual																																																											
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																											
C	2007	Yukon XL	Body	Lift Gate Module																									V	V																																	
C	2007	Yukon XL	Body	Memory Seat Module																																																											
C	2007	Yukon XL	Body	Park Assist Module																																																											
C	2007	Yukon XL	Body	Passenger Door Switch																																																											
C	2007	Yukon XL	Body	Passenger Presence System																																																											
C	2007	Yukon XL	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2007	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2007	Yukon XL	Body	Rollover Sensor																																																												
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2007	Yukon XL	Body	Theft Deterrent Module																																																												
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES			V																																																									
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Sierra	Chassis	Electronic Suspension Control																																																											
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																											
C	2008	Sierra	Body	Amplifier (Bose)																																																											
C	2008	Sierra	Body	Body Control Module																																																										
C	2008	Sierra	Body	Body Control Module (aux.)																																																										
C	2008	Sierra	Body	Digital Radio Receiver																																																										
C	2008	Sierra	Body	Driver Door Switch																																																										
C	2008	Sierra	Body	HVAC Control Module Auto																																																										
C	2008	Sierra	Body	HVAC Control Module Manual																																																										
C	2008	Sierra	Body	Instrument Panel Cluster																																																										
C	2008	Sierra	Body	Memory Seat Module																																																										
C	2008	Sierra	Body	Park Assist Module																																																										
C	2008	Sierra	Body	Passenger Door Switch																																																										
C	2008	Sierra	Body	Passenger Presence System																																																										
C	2008	Sierra	Body	Radio																																																										
C	2008	Sierra	Body	Rear Heated Seat Module																																																											
C	2008	Sierra	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2008	Sierra	Body	Rollover Sensor																																																												
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2008	Sierra	Body	Theft Deterrent Module																																																												
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Yukon	Chassis	Electronic Brake Control Module			V																																																									
C	2008	Yukon	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon	Body	Amplifier (Bose)																																																												
C	2008	Yukon	Body	Assist Step Controller																																																												
C	2008	Yukon	Body	Body Control Module																																																												
C	2008	Yukon	Body	Body Control Module (aux.)																																																												
C	2008	Yukon	Body	Digital Radio Receiver																																																												
C	2008	Yukon	Body	Driver Door Switch																																																												
C	2008	Yukon	Body	HVAC Control Module Auto																																																												
C	2008	Yukon	Body	HVAC Control Module Manual																																																												
C	2008	Yukon	Body	Instrument Panel Cluster																																																												
C	2008	Yukon	Body	Lift Gate Module																									V	V																																		
C	2008	Yukon	Body	Memory Seat Module																																																												
C	2008	Yukon	Body	Park Assist Module																																																												
C	2008	Yukon	Body	Passenger Door Switch																																																												
C	2008	Yukon	Body	Passenger Presence System																																																												
C	2008	Yukon	Body	Radio																																																												
C	2008	Yukon	Body	Rear Heated Seat Module																																																												
C	2008	Yukon	Body	Rear HVAC/RSA																																																												
C	2008	Yukon	Body	Rollover Sensor																																																												
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon	Body	Theft Deterrent Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																											
C	2008	Yukon Hybrid	Body	Body Control Module																																																												
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																												
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																												
C	2008	Yukon Hybrid	Body	HVAC Control Module																																																												
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
C	2008	Yukon Hybrid	Body	Lift Gate Module																									V	V																																		
C	2008	Yukon Hybrid	Body	Memory Seat Module																																																												
C	2008	Yukon Hybrid	Body	Park Assist Module																																																												
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																												
C	2008	Yukon Hybrid	Body	Passenger Presence System																																																												
C	2008	Yukon Hybrid	Body	Radio																																																												
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																												
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon XL	Body	Amplifier (Bose)																																																												
C	2008	Yukon XL	Body	Assist Step Controller																																																												
C	2008	Yukon XL	Body	Body Control Module																																																												
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2008	Yukon XL	Body	Digital Radio Receiver																																																												
C	2008	Yukon XL	Body	Driver Door Switch																																																												
C	2008	Yukon XL	Body	HVAC Control Module Auto																																																												
C	2008	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2008	Yukon XL	Body	Lift Gate Module																									V	V																																		
C	2008	Yukon XL	Body	Memory Seat Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2008	Yukon XL	Body	Park Assist Module																																																														
C	2008	Yukon XL	Body	Passenger Door Switch																																																														
C	2008	Yukon XL	Body	Passenger Presence System																																																														
C	2008	Yukon XL	Body	Radio																																																														
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																														
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																														
C	2008	Yukon XL	Body	Rollover Sensor																																																														
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																														
C	2008	Yukon XL	Body	Theft Deterrent Module																																																														
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																				
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																															
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																															
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module										V																																																				
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																				
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																															
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																															
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																															
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																															
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																				
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																															
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																															
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																				
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																															
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																															
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																															
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																															
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																															
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																															
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																				
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																				
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual										V																																																				
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES			V																																																												
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																															
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																															
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																															
C	2009	Sierra	Chassis	Electronic Suspension Control																																																															
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																															
C	2009	Sierra	Body	Amplifier (Bose)																																																															
C	2009	Sierra	Body	Body Control Module															V	V	V	V	V	V	V																																									
C	2009	Sierra	Body	Body Control Module (aux.)																																																															
C	2009	Sierra	Body	Digital Radio Receiver																																																															
C	2009	Sierra	Body	Driver Door Switch																																																															
C	2009	Sierra	Body	HVAC Control Module Auto																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2009	Sierra	Body	HVAC Control Module Manual																																																														
C	2009	Sierra	Body	Instrument Panel Cluster																																																														
C	2009	Sierra	Body	Memory Seat Module																																																														
C	2009	Sierra	Body	Park Assist Module																																																														
C	2009	Sierra	Body	Passenger Door Switch																																																														
C	2009	Sierra	Body	Passenger Presence System																																																														
C	2009	Sierra	Body	Radio																																																														
C	2009	Sierra	Body	Rear Heated Seat Module																																																														
C	2009	Sierra	Body	Rear HVAC/RSA																																																														
C	2009	Sierra	Body	Rollover Sensor																																																														
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																																														
C	2009	Sierra	Body	Theft Deterrent Module																																																														
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																														
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																														
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																														
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																														
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																														
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																														
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																														
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																														
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																														
C	2009	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																								
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																														
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																														
C	2009	Sierra Hybrid	Body	Driver Door Switch																																																														
C	2009	Sierra Hybrid	Body	HVAC Control Module																																																														
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																														
C	2009	Sierra Hybrid	Body	Memory Seat Module																																																														
C	2009	Sierra Hybrid	Body	Park Assist Module																																																														
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																																														
C	2009	Sierra Hybrid	Body	Passenger Presence System																																																														
C	2009	Sierra Hybrid	Body	Radio																																																														
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																														
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																														
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																														
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																														
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																														
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																														
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed										V																																																				
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed										V																																																				
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																														
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																														
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																			
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																														
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																			
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																			
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed										V																																																			
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed										V																																																			
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																													
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																													
C	2009	Yukon	Chassis	Electronic Brake Control Module			V																																																										
C	2009	Yukon	Chassis	Electronic Suspension Control																																																														
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																														
C	2009	Yukon	Body	Amplifier (Bose)																																																														
C	2009	Yukon	Body	Assist Step Controller																																																														
C	2009	Yukon	Body	Body Control Module															V	V	V	V	V	V	V																																								
C	2009	Yukon	Body	Body Control Module (aux.)																																																														
C	2009	Yukon	Body	Digital Radio Receiver																																																														
C	2009	Yukon	Body	Driver Door Switch																																																														
C	2009	Yukon	Body	HVAC Control Module Auto																																																														
C	2009	Yukon	Body	HVAC Control Module Manual																																																														
C	2009	Yukon	Body	Instrument Panel Cluster																																																														
C	2009	Yukon	Body	Left Side Object Detection Module						V																																																							
C	2009	Yukon	Body	Lift Gate Module																									V	V																																				
C	2009	Yukon	Body	Memory Seat Module																																																														
C	2009	Yukon	Body	Park Assist Module																																																														
C	2009	Yukon	Body	Passenger Door Switch																																																														
C	2009	Yukon	Body	Passenger Presence System																																																														
C	2009	Yukon	Body	Radio																																																														
C	2009	Yukon	Body	Rear Heated Seat Module																																																														
C	2009	Yukon	Body	Rear HVAC/RSA																																																														
C	2009	Yukon	Body	Right Side Object Detection Module						V																																																								
C	2009	Yukon	Body	Rollover Sensor																																																														
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																																														
C	2009	Yukon	Body	Theft Deterrent Module																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																														
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																														
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																														
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																														
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																														
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																														
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																														
C	2009	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																								

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																																
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																																
C	2009	Yukon Hybrid	Body	Driver Door Switch																																																																
C	2009	Yukon Hybrid	Body	Heated Seat Module																																																																
C	2009	Yukon Hybrid	Body	HVAC Control Module																																																																
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																																
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module						V																																																									
C	2009	Yukon Hybrid	Body	Park Assist Module																																																																
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																																																
C	2009	Yukon Hybrid	Body	Passenger Presence System																																																																
C	2009	Yukon Hybrid	Body	Radio																																																																
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																																
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																																
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module						V																																																									
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																																
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																																
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																																
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																																
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																					
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																																
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																																
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																																
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																																
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																					
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																																
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																																
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																					
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																																
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																																
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																					
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																																
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																																
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																					
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW			V																																																													
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																																
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																																
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																																
C	2009	Yukon XL	Body	Amplifier (Bose)																																																																
C	2009	Yukon XL	Body	Assist Step Controller																																																																
C	2009	Yukon XL	Body	Body Control Module															V	V	V	V	V	V	V																																										
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																																
C	2009	Yukon XL	Body	Digital Radio Receiver																																																																
C	2009	Yukon XL	Body	Driver Door Switch																																																																
C	2009	Yukon XL	Body	HVAC Control Module Auto																																																																
C	2009	Yukon XL	Body	HVAC Control Module Manual																																																																
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																																
C	2009	Yukon XL	Body	Left Side Object Detection Module						V																																																									
C	2009	Yukon XL	Body	Lift Gate Module																									V	V																																					
C	2009	Yukon XL	Body	Memory Seat Module																																																																

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2009	Yukon XL	Body	Park Assist Module																																																															
C	2009	Yukon XL	Body	Passenger Door Switch																																																															
C	2009	Yukon XL	Body	Passenger Presence System																																																															
C	2009	Yukon XL	Body	Radio																																																															
C	2009	Yukon XL	Body	Rear Heated Seat Module																																																															
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																															
C	2009	Yukon XL	Body	Right Side Object Detection Module						V																																																								
C	2009	Yukon XL	Body	Rollover Sensor																																																															
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																															
C	2009	Yukon XL	Body	Theft Deterrent Module																																																															
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																															
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																															
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																															
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																															
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																															
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																															
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																															
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																															
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																															
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																															
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																															
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																				
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																				
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES			V																																																												
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																															
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																															
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																															
C	2010	Sierra	Chassis	Electronic Suspension Control																																																															
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																															
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																															
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																															
C	2010	Sierra	Body	Amplifier (Bose)																																																															
C	2010	Sierra	Body	Body Control Module															V	V	V	V	V	V	V																																									
C	2010	Sierra	Body	Body Control Module (aux.)																																																															
C	2010	Sierra	Body	Digital Radio Receiver																																																															
C	2010	Sierra	Body	Driver Door Switch																																																															
C	2010	Sierra	Body	HVAC Control Module Auto																																																															
C	2010	Sierra	Body	HVAC Control Module Manual																																																															
C	2010	Sierra	Body	Instrument Panel Cluster																																																															
C	2010	Sierra	Body	Memory Seat Module																																																															
C	2010	Sierra	Body	Park Assist Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2010	Sierra	Body	Passenger Door Switch																																																														
C	2010	Sierra	Body	Passenger Presence System																																																														
C	2010	Sierra	Body	Radio																																																													
C	2010	Sierra	Body	Rear Heated Seat Module																																																													
C	2010	Sierra	Body	Rear HVAC/RSA																																																													
C	2010	Sierra	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
C	2010	Sierra	Body	Theft Deterrent Module																																																													
C	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																													
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																													
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																													
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																													
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																													
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																													
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																													
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																													
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																													
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																													
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																													
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																													
C	2010	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																							
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																													
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																													
C	2010	Sierra Hybrid	Body	Driver Door Switch																																																													
C	2010	Sierra Hybrid	Body	Heated Seat Module																																																													
C	2010	Sierra Hybrid	Body	HVAC Control Module																																																													
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																													
C	2010	Sierra Hybrid	Body	Park Assist Module																																																													
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																																													
C	2010	Sierra Hybrid	Body	Passenger Presence System																																																													
C	2010	Sierra Hybrid	Body	Radio																																																													
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																													
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																													
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																													
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																													
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																																			
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																													
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																			
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2010	Yukon	Chassis	Electronic Brake Control Module			V																																																										
C	2010	Yukon	Chassis	Electronic Suspension Control																																																													
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Yukon	Body	Amplifier (Bose)																																																													
C	2010	Yukon	Body	Assist Step Controller																																																													
C	2010	Yukon	Body	Body Control Module															V	V	V	V	V	V	V																																							

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2010	Yukon	Body	Body Control Module (aux.)																																																														
C	2010	Yukon	Body	Digital Radio Receiver																																																														
C	2010	Yukon	Body	Driver Door Switch																																																														
C	2010	Yukon	Body	HVAC Control Module Auto																																																														
C	2010	Yukon	Body	HVAC Control Module Manual																																																														
C	2010	Yukon	Body	Instrument Panel Cluster																																																														
C	2010	Yukon	Body	Left Side Object Detection Module						V																																																							
C	2010	Yukon	Body	Lift Gate Module																								V	V			V	V																																	
C	2010	Yukon	Body	Memory Seat Module																																																														
C	2010	Yukon	Body	Park Assist Module																																																														
C	2010	Yukon	Body	Passenger Door Switch																																																														
C	2010	Yukon	Body	Passenger Presence System																																																														
C	2010	Yukon	Body	Radio																																																														
C	2010	Yukon	Body	Rear Heated Seat Module																																																														
C	2010	Yukon	Body	Rear HVAC/RSA																																																														
C	2010	Yukon	Body	Right Side Object Detection Module						V																																																								
C	2010	Yukon	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
C	2010	Yukon	Body	Theft Deterrent Module																																																														
C	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																															
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																															
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																														
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																														
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																														
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																														
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																														
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																														
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																														
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																														
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																														
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																														
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																														
C	2010	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																								
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																														
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																														
C	2010	Yukon Hybrid	Body	Driver Door Switch																																																														
C	2010	Yukon Hybrid	Body	Heated Seat Module																																																														
C	2010	Yukon Hybrid	Body	HVAC Control Module																																																														
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																														
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module						V																																																							
C	2010	Yukon Hybrid	Body	Lift Gate Module																								V	V			V	V																																	
C	2010	Yukon Hybrid	Body	Park Assist Module																																																														
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																																														
C	2010	Yukon Hybrid	Body	Passenger Presence System																																																														
C	2010	Yukon Hybrid	Body	Radio																																																														
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																														
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																														
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module						V																																																							
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																														
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																														
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																																			
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																													
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																			
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																			
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW			V																																																											
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																														
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																														
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																														
C	2010	Yukon XL	Body	Amplifier (Bose)																																																														
C	2010	Yukon XL	Body	Assist Step Controller																																																														
C	2010	Yukon XL	Body	Body Control Module															V	V	V	V	V	V	V																																								
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																														
C	2010	Yukon XL	Body	Digital Radio Receiver																																																														
C	2010	Yukon XL	Body	Driver Door Switch																																																														
C	2010	Yukon XL	Body	HVAC Control Module Auto																																																														
C	2010	Yukon XL	Body	HVAC Control Module Manual																																																														
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																														
C	2010	Yukon XL	Body	Left Side Object Detection Module						V																																																							
C	2010	Yukon XL	Body	Lift Gate Module																									V	V			V	V																																
C	2010	Yukon XL	Body	Memory Seat Module																																																														
C	2010	Yukon XL	Body	Park Assist Module																																																														
C	2010	Yukon XL	Body	Passenger Door Switch																																																														
C	2010	Yukon XL	Body	Passenger Presence System																																																														
C	2010	Yukon XL	Body	Radio																																																														
C	2010	Yukon XL	Body	Rear Heated Seat Module																																																														
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																														
C	2010	Yukon XL	Body	Right Side Object Detection Module						V																																																							
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
C	2010	Yukon XL	Body	Theft Deterrent Module																																																														
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																														
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																														
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																														
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																														
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																														
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																														
D	2008	ALL	Chassis	Electronic Brake Control Module																																																														
D	2008	ALL	Body	Body Control Module																																																														
D	2008	ALL	Body	Body Control Module (aux.)																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
D	2008	ALL	Body	Headlamp Control Module									V																																																			
D	2008	ALL	Body	HVAC Control Module Auto																																																												
D	2008	ALL	Body	Instrument Panel Cluster																																																												
D	2008	ALL	Body	Park Assist Module																																																												
D	2008	ALL	Body	Remote Control Door Lock Receiver																																																												
D	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
D	2008	ALL	Body	Theft Deterrent Module																																																												
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																												
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																												
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																												
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																												
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																												
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																												
D	2009	ALL	Chassis	Electronic Brake Control Module																																																												
D	2009	ALL	Body	Body Control Module																																																												
D	2009	ALL	Body	Body Control Module (aux.)																																																												
D	2009	ALL	Body	Headlamp Control Module									V																																																			
D	2009	ALL	Body	HVAC Control Module Auto																																																												
D	2009	ALL	Body	Instrument Panel Cluster																																																												
D	2009	ALL	Body	Park Assist Module																																																												
D	2009	ALL	Body	Remote Control Door Lock Receiver																																																												
D	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
D	2009	ALL	Body	Theft Deterrent Module																																																												
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																												
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																												
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																												
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module										V																																																	
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																												
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																												
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																												
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																												
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																												
D	2010	ALL	Chassis	Electronic Brake Control Module																																																												
D	2010	ALL	Body	Body Control Module																																																												
D	2010	ALL	Body	Body Control Module (aux.)																																																												
D	2010	ALL	Body	Headlamp Control Module									V																																																			
D	2010	ALL	Body	HVAC Control Module Auto																																																												
D	2010	ALL	Body	Instrument Panel Cluster																																																												
D	2010	ALL	Body	Park Assist Module																																																												
D	2010	ALL	Body	Remote Control Door Lock Receiver																																																												
D	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																										
G	2004	Express/Savana	Body	Body Control Module																																																										
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2004	Express/Savana	Body	OnStar																																																										
G	2004	Express/Savana	Body	Base Radio																																																										
G	2004	Express/Savana	Body	Uplevel Radio																																																										
G	2004	Express/Savana	Body	Remote Function Actuation																																																										
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																																										
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																											
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																											
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																											
G	2005	Express/Savana	Chassis	VSES																																																											
G	2005	Express/Savana	Body	Body Control Module																																																											
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																											
G	2005	Express/Savana	Body	Base Radio																																																											
G	2005	Express/Savana	Body	Uplevel Radio																																																											
G	2005	Express/Savana	Body	Remote Function Actuation																																																											
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																											
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																											
G	2005	Express Access/Savana Pro	Chassis	VSES																																																											
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
G	2005	Express Access/Savana Pro	Body	Base Radio																																																											
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																											
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																											
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																											
G	2006	Express/Savana	Chassis	VSES																																																											
G	2006	Express/Savana	Body	Body Control Module																																																											
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																											
G	2006	Express/Savana	Body	Passenger Presence System																																																											
G	2006	Express/Savana	Body	Base Radio																																																											
G	2006	Express/Savana	Body	Uplevel Radio																																																											
G	2006	Express/Savana	Body	Remote Function Actuation																																																											
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																											
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																											
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																											
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																											
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																											
G	2006	Express Access/Savana Pro	Chassis	VSES																																																											
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2006	Express Access/Savana Pro	Body	Base Radio																																																											
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																											
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																											
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																											
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																											
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2007	Express/Savana	Body	Body Control Module																																																											
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																											
G	2007	Express/Savana	Body	Passenger Presence System																																																											
G	2007	Express/Savana	Body	Base Radio																																																											
G	2007	Express/Savana	Body	Uplevel Radio																																																											
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																												
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2007	Express Access/Savana Pro	Body	Radio																																																												
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2008	Express/Savana	Body	Body Control Module																																																												
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2008	Express/Savana	Body	Passenger Presence System																																																												
G	2008	Express/Savana	Body	Radio																																																												
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2008	Express/Savana	Body	Rollover Sensor																																																												
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2008	Express/Savana	Body	Theft Deterrent Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																													
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2008	Express Access/Savana Pro	Body	Radio																																																												
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module										V																																																		
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																		
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module										V																																																		
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module										V																																																		
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2009	Express/Savana	Body	Body Control Module																																																												
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2009	Express/Savana	Body	Passenger Presence System																																																												
G	2009	Express/Savana	Body	Radio																																																												
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2009	Express/Savana	Body	Rollover Sensor																																																												
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2009	Express/Savana	Body	Theft Deterrent Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module										V																																																		
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																		
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module										V																																																		
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module										V																																																		
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2009	Express Access/Savana Pro	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																														
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																														
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																															
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																															
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																															
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																															
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																															
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																															
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																															
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																															
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																															
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																															
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																				
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																															
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																															
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																															
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																															
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																															
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																															
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																															
G	2010	Express/Savana	Body	Body Control Module																																																															
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																															
G	2010	Express/Savana	Body	Passenger Presence System																																																															
G	2010	Express/Savana	Body	Radio																																																															
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																															
G	2010	Express/Savana	Body	Rollover Sensor																																																															
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																															
G	2010	Express/Savana	Body	Theft Deterrent Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																				
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																															
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																															
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																															
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																															
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2010	Express Access/Savana Pro	Body	Radio																																																											
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																											
H	2004	Express/Savana	Chassis	VSES																																																											
H	2004	Express/Savana	Body	Body Control Module																																																											
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2004	Express/Savana	Body	OnStar																																																											
H	2004	Express/Savana	Body	Base Radio																																																											
H	2004	Express/Savana	Body	Uplevel Radio																																																											
H	2004	Express/Savana	Body	Remote Function Actuation																																																											
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																											
H	2004	Express Access/Savana Pro	Chassis	VSES																																																											
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
H	2004	Express Access/Savana Pro	Body	OnStar																																																											
H	2004	Express Access/Savana Pro	Body	Base Radio																																																											
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																											
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																											
H	2005	Express/Savana	Chassis	VSES																																																											
H	2005	Express/Savana	Body	Body Control Module																																																											
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2005	Express/Savana	Body	Base Radio																																																											
H	2005	Express/Savana	Body	Uplevel Radio																																																											
H	2005	Express/Savana	Body	Remote Function Actuation																																																											
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																											
H	2005	Express Access/Savana Pro	Chassis	VSES																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2005	Express Access/Savana Pro	Body	Base Radio																																																												
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																												
H	2006	Express/Savana	Chassis	VSES																																																												
H	2006	Express/Savana	Body	Body Control Module																																																												
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																												
H	2006	Express/Savana	Body	Passenger Presence System																																																												
H	2006	Express/Savana	Body	Base Radio																																																												
H	2006	Express/Savana	Body	Uplevel Radio																																																												
H	2006	Express/Savana	Body	Remote Function Actuation																																																												
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2006	Express Access/Savana Pro	Chassis	VSES																																																												
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2006	Express Access/Savana Pro	Body	Base Radio																																																												
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2007	Express/Savana	Body	Body Control Module																																																											
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2007	Express/Savana	Body	Passenger Presence System																																																											
H	2007	Express/Savana	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2007	Express/Savana	Body	Uplevel Radio																																																										
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2007	Express Access/Savana Pro	Body	Base Radio																																																										
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express/Savana	Body	Body Control Module																																																										
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2008	Express/Savana	Body	Passenger Presence System																																																										
H	2008	Express/Savana	Body	Radio																																																										
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express/Savana	Body	Rollover Sensor																																																										
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express/Savana	Body	Theft Deterrent Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2008	Express Access/Savana Pro	Body	Radio																																																												
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module										V																																																		
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																		
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module										V																																																		
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module										V																																																		
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2009	Express/Savana	Body	Body Control Module																																																												
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2009	Express/Savana	Body	Passenger Presence System																																																												
H	2009	Express/Savana	Body	Radio																																																												
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2009	Express/Savana	Body	Rollover Sensor																																																												
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2009	Express/Savana	Body	Theft Deterrent Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module										V																																																		
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																		
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module										V																																																		
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module										V																																																		
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2009	Express Access/Savana Pro	Body	Radio																																																												
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2010	Express/Savana	Body	Body Control Module																																																												
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2010	Express/Savana	Body	Passenger Presence System																																																												
H	2010	Express/Savana	Body	Radio																																																												
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2010	Express/Savana	Body	Rollover Sensor																																																												
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2010	Express/Savana	Body	Theft Deterrent Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2010	Express Access/Savana Pro	Body	Radio																																																												
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																															
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																															
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																															
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																															
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																															
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																															
K	2004	ALL	Chassis	ESC																																																															
K	2004	ALL	Chassis	Rear Wheel Steering																																																															
K	2004	ALL	Chassis	Tire Pressure Monitor																																																															
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																															
K	2004	ALL	Chassis	VSES																																																															
K	2004	ALL	Body	Amplifier (Bose)																																																															
K	2004	ALL	Body	Body Control Module																																																															
K	2004	ALL	Body	CD Changer																																																															
K	2004	ALL	Body	Chime																																																															
K	2004	ALL	Body	Driver Door Module																																																															
K	2004	ALL	Body	Driver Seat Module																																																															
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																															
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																															
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																															
K	2004	ALL	Body	Instrument Panel Cluster																																																															
K	2004	ALL	Body	OnStar																																																															
K	2004	ALL	Body	Passenger Door Module																																																															
K	2004	ALL	Body	Passenger Presence System																																																															
K	2004	ALL	Body	Radio Base																																																															
K	2004	ALL	Body	Radio Uplevel																																																															
K	2004	ALL	Body	Radio Navigation																																																															
K	2004	ALL	Body	Rear Aux. Climate Module																																																															
K	2004	ALL	Body	Rear HVAC																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2004	ALL	Body	Rear Seat Audio																																																														
K	2004	ALL	Body	Rear Seat Entertainment																																																														
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2004	ALL	Body	Vehicle Theft Deterrent																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																														
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																														
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																														
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																														
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																														
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																														
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																											
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2005	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
K	2006	ALL	Chassis	ESC																																																											
K	2006	ALL	Chassis	Tire Pressure Monitor																																																											
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																											
K	2006	ALL	Chassis	VSES																																																										
K	2006	ALL	Body	Amplifier (Bose)																																																											
K	2006	ALL	Body	Body Control Module																																																											
K	2006	ALL	Body	CD Changer																																																											
K	2006	ALL	Body	Chime																																																											
K	2006	ALL	Body	Disc Player and Video Display																																																											
K	2006	ALL	Body	Driver Door Module																																																											
K	2006	ALL	Body	Driver Seat Module																																																											
K	2006	ALL	Body	Generator Battery Control Module																																																											
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2006	ALL	Body	Instrument Panel Cluster																																																											
K	2006	ALL	Body	Passenger Door Module																																																											
K	2006	ALL	Body	Passenger Presence System																																																											
K	2006	ALL	Body	Base Radio																																																											
K	2006	ALL	Body	Uplevel Radio																																																											
K	2006	ALL	Body	Navigation Radio																																																											
K	2006	ALL	Body	Rear Aux. Climate Module																																																											
K	2006	ALL	Body	Rear HVAC																																																											
K	2006	ALL	Body	Rear Seat Audio																																																											
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2006	ALL	Body	Vehicle Theft Deterrent																																																											
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																											
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2007	Sierra	Chassis	Electronic Suspension Control																																																													
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																													
K	2007	Sierra	Body	Amplifier (Bose)																																																													
K	2007	Sierra	Body	Body Control Module																																																													
K	2007	Sierra	Body	Body Control Module (aux.)																																																													
K	2007	Sierra	Body	Digital Radio Receiver																																																													
K	2007	Sierra	Body	Driver Door Switch																																																													
K	2007	Sierra	Body	HVAC Control Module Auto																																																													
K	2007	Sierra	Body	HVAC Control Module Manual																																																													
K	2007	Sierra	Body	Instrument Panel Cluster																																																													
K	2007	Sierra	Body	Memory Seat Module																																																													
K	2007	Sierra	Body	Park Assist Module																																																													
K	2007	Sierra	Body	Passenger Door Switch																																																													
K	2007	Sierra	Body	Passenger Presence System																																																													
K	2007	Sierra	Body	Radio																																																													
K	2007	Sierra	Body	Rear Heated Seat Module																																																													
K	2007	Sierra	Body	Rear HVAC/RSA																																																													
K	2007	Sierra	Body	Rollover Sensor																																																													
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																																													
K	2007	Sierra	Body	Theft Deterrent Module																																																													
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																													
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																													
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																													
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2007	Yukon	Chassis	Electronic Suspension Control																																																													
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																													
K	2007	Yukon	Body	Amplifier (Bose)																																																													
K	2007	Yukon	Body	Assist Step Controller																																																													
K	2007	Yukon	Body	Body Control Module																																																													
K	2007	Yukon	Body	Body Control Module (aux.)																																																													
K	2007	Yukon	Body	Digital Radio Receiver																																																													
K	2007	Yukon	Body	Driver Door Switch																																																													
K	2007	Yukon	Body	HVAC Control Module Auto																																																													
K	2007	Yukon	Body	HVAC Control Module Manual																																																													
K	2007	Yukon	Body	Instrument Panel Cluster																																																													
K	2007	Yukon	Body	Lift Gate Module																									V	V																																		
K	2007	Yukon	Body	Memory Seat Module																																																													
K	2007	Yukon	Body	Park Assist Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2007	Yukon	Body	Passenger Door Switch																																																										
K	2007	Yukon	Body	Passenger Presence System																																																										
K	2007	Yukon	Body	Radio																																																										
K	2007	Yukon	Body	Rear Heated Seat Module																																																										
K	2007	Yukon	Body	Rear HVAC/RSA																																																										
K	2007	Yukon	Body	Rollover Sensor																																																										
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																																										
K	2007	Yukon	Body	Theft Deterrent Module																																																										
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2007	Yukon XL	Body	Amplifier (Bose)																																																										
K	2007	Yukon XL	Body	Assist Step Controller																																																										
K	2007	Yukon XL	Body	Body Control Module																																																										
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2007	Yukon XL	Body	Digital Radio Receiver																																																										
K	2007	Yukon XL	Body	Driver Door Switch																																																										
K	2007	Yukon XL	Body	HVAC Control Module Auto																																																										
K	2007	Yukon XL	Body	HVAC Control Module Manual																																																										
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2007	Yukon XL	Body	Lift Gate Module																									V	V																																
K	2007	Yukon XL	Body	Memory Seat Module																																																										
K	2007	Yukon XL	Body	Park Assist Module																																																										
K	2007	Yukon XL	Body	Passenger Door Switch																																																										
K	2007	Yukon XL	Body	Passenger Presence System																																																										
K	2007	Yukon XL	Body	Radio																																																										
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2007	Yukon XL	Body	Rollover Sensor																																																										
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2007	Yukon XL	Body	Theft Deterrent Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES			V																																																									
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2008	Sierra	Chassis	Electronic Suspension Control																																																											
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																											
K	2008	Sierra	Body	Amplifier (Bose)																																																											
K	2008	Sierra	Body	Body Control Module																																																										
K	2008	Sierra	Body	Body Control Module (aux.)																																																										
K	2008	Sierra	Body	Digital Radio Receiver																																																										
K	2008	Sierra	Body	Driver Door Switch																																																										
K	2008	Sierra	Body	HVAC Control Module Auto																																																										
K	2008	Sierra	Body	HVAC Control Module Manual																																																										
K	2008	Sierra	Body	Instrument Panel Cluster																																																										
K	2008	Sierra	Body	Memory Seat Module																																																										
K	2008	Sierra	Body	Park Assist Module																																																										
K	2008	Sierra	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2008	Sierra	Body	Passenger Presence System																																																															
K	2008	Sierra	Body	Radio																																																															
K	2008	Sierra	Body	Rear Heated Seat Module																																																															
K	2008	Sierra	Body	Rear HVAC/RSA																																																															
K	2008	Sierra	Body	Rollover Sensor																																																															
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																																															
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																															
K	2008	Sierra	Body	Theft Deterrent Module																																																															
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																															
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																															
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																															
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																															
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																															
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																															
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																															
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																															
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																															
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																															
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																															
K	2008	Yukon	Chassis	Electronic Brake Control Module			V																																																												
K	2008	Yukon	Chassis	Electronic Suspension Control																																																																
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																																
K	2008	Yukon	Body	Amplifier (Bose)																																																																
K	2008	Yukon	Body	Assist Step Controller																																																																
K	2008	Yukon	Body	Body Control Module																																																																
K	2008	Yukon	Body	Body Control Module (aux.)																																																																
K	2008	Yukon	Body	Digital Radio Receiver																																																																
K	2008	Yukon	Body	Driver Door Switch																																																																
K	2008	Yukon	Body	HVAC Control Module Auto																																																																
K	2008	Yukon	Body	HVAC Control Module Manual																																																																
K	2008	Yukon	Body	Instrument Panel Cluster																																																																
K	2008	Yukon	Body	Lift Gate Module																									V	V																																					
K	2008	Yukon	Body	Memory Seat Module																																																																
K	2008	Yukon	Body	Park Assist Module																																																																
K	2008	Yukon	Body	Passenger Door Switch																																																																
K	2008	Yukon	Body	Passenger Presence System																																																																
K	2008	Yukon	Body	Radio																																																																
K	2008	Yukon	Body	Rear Heated Seat Module																																																																
K	2008	Yukon	Body	Rear HVAC/RSA																																																																
K	2008	Yukon	Body	Rollover Sensor																																																																
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																																																
K	2008	Yukon	Body	Theft Deterrent Module																																																																
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																																
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																																
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																																
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																																
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																																
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																																

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																											
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																											
K	2008	Yukon Hybrid	Body	Body Control Module																																																											
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																											
K	2008	Yukon Hybrid	Body	Driver Door Switch																																																											
K	2008	Yukon Hybrid	Body	HVAC Control Module																																																											
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
K	2008	Yukon Hybrid	Body	Lift Gate Module																									V	V																																	
K	2008	Yukon Hybrid	Body	Memory Seat Module																																																											
K	2008	Yukon Hybrid	Body	Park Assist Module																																																											
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																																											
K	2008	Yukon Hybrid	Body	Passenger Presence System																																																											
K	2008	Yukon Hybrid	Body	Radio																																																											
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																											
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																											
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																											
K	2008	Yukon XL	Body	Amplifier (Bose)																																																											
K	2008	Yukon XL	Body	Assist Step Controller																																																											
K	2008	Yukon XL	Body	Body Control Module																																																											
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																											
K	2008	Yukon XL	Body	Digital Radio Receiver																																																											
K	2008	Yukon XL	Body	Driver Door Switch																																																											
K	2008	Yukon XL	Body	HVAC Control Module Auto																																																											
K	2008	Yukon XL	Body	HVAC Control Module Manual																																																											
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																											
K	2008	Yukon XL	Body	Lift Gate Module																									V	V																																	
K	2008	Yukon XL	Body	Memory Seat Module																																																											
K	2008	Yukon XL	Body	Park Assist Module																																																											
K	2008	Yukon XL	Body	Passenger Door Switch																																																											
K	2008	Yukon XL	Body	Passenger Presence System																																																											
K	2008	Yukon XL	Body	Radio																																																											
K	2008	Yukon XL	Body	Rear Heated Seat Module																																																											
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																											
K	2008	Yukon XL	Body	Rollover Sensor																																																											
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
K	2008	Yukon XL	Body	Theft Deterrent Module																																																											
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																	
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module										V																																																	
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																	
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																												
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul																																																												
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																	
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																	
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																			
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																			
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																													
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																			
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																													
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																													
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES			V																																																										
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																													
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													
K	2009	Sierra	Chassis	Electronic Suspension Control																																																													
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																													
K	2009	Sierra	Body	Amplifier (Bose)																																																													
K	2009	Sierra	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2009	Sierra	Body	Body Control Module (aux.)																																																													
K	2009	Sierra	Body	Digital Radio Receiver																																																													
K	2009	Sierra	Body	Driver Door Switch																																																													
K	2009	Sierra	Body	HVAC Control Module Auto																																																													
K	2009	Sierra	Body	HVAC Control Module Manual																																																													
K	2009	Sierra	Body	Instrument Panel Cluster																																																													
K	2009	Sierra	Body	Memory Seat Module																																																													
K	2009	Sierra	Body	Park Assist Module																																																													
K	2009	Sierra	Body	Passenger Door Switch																																																													
K	2009	Sierra	Body	Passenger Presence System																																																													
K	2009	Sierra	Body	Radio																																																													
K	2009	Sierra	Body	Rear Heated Seat Module																																																													
K	2009	Sierra	Body	Rear HVAC/RSA																																																													
K	2009	Sierra	Body	Rollover Sensor																																																													
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																																													
K	2009	Sierra	Body	Theft Deterrent Module																																																													
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																													
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																													
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																													
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																													
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																													
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																													
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																													
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																														
K	2009	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																								
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																														
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																														
K	2009	Sierra Hybrid	Body	Driver Door Switch																																																														
K	2009	Sierra Hybrid	Body	HVAC Control Module																																																														
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																														
K	2009	Sierra Hybrid	Body	Memory Seat Module																																																														
K	2009	Sierra Hybrid	Body	Park Assist Module																																																														
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																																														
K	2009	Sierra Hybrid	Body	Passenger Presence System																																																														
K	2009	Sierra Hybrid	Body	Radio																																																														
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																														
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																														
K	2009	Sierra Hybrid	Body	Rollover Sensor																																																														
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																														
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																														
K	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																														
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																				
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																														
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																														
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																														
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module										V																																																				
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																														
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																														
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																				
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																														
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																				
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																														
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																				
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																														
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																														
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
K	2009	Yukon	Chassis	Electronic Brake Control Module			V																																																											
K	2009	Yukon	Chassis	Electronic Suspension Control																																																														
K	2009	Yukon	Chassis	Trailer Brake Control Module																																																														
K	2009	Yukon	Body	Amplifier (Bose)																																																														
K	2009	Yukon	Body	Assist Step Controller																																																														
K	2009	Yukon	Body	Body Control Module															V	V	V	V	V	V	V																																								
K	2009	Yukon	Body	Body Control Module (aux.)																																																														
K	2009	Yukon	Body	Digital Radio Receiver																																																														
K	2009	Yukon	Body	Driver Door Switch																																																														
K	2009	Yukon	Body	HVAC Control Module Auto																																																														
K	2009	Yukon	Body	HVAC Control Module Manual																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2009	Yukon	Body	Instrument Panel Cluster																																																															
K	2009	Yukon	Body	Left Side Object Detection Module						V																																																								
K	2009	Yukon	Body	Lift Gate Module																									V	V																																					
K	2009	Yukon	Body	Memory Seat Module																																																															
K	2009	Yukon	Body	Park Assist Module																																																															
K	2009	Yukon	Body	Passenger Door Switch																																																															
K	2009	Yukon	Body	Passenger Presence System																																																															
K	2009	Yukon	Body	Radio																																																															
K	2009	Yukon	Body	Rear Heated Seat Module																																																															
K	2009	Yukon	Body	Rear HVAC/RSA																																																															
K	2009	Yukon	Body	Right Side Object Detection Module						V																																																									
K	2009	Yukon	Body	Rollover Sensor																																																															
K	2009	Yukon	Body	Supplemental Inflatable Restraint																																																															
K	2009	Yukon	Body	Theft Deterrent Module																																																															
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																															
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																															
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																															
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																															
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																															
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																															
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																															
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																															
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																															
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																															
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																															
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																															
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																															
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																															
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																															
K	2009	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																									
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																															
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																															
K	2009	Yukon Hybrid	Body	Driver Door Switch																																																															
K	2009	Yukon Hybrid	Body	Heated Seat Module																																																															
K	2009	Yukon Hybrid	Body	HVAC Control Module																																																															
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																															
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module						V																																																								
K	2009	Yukon Hybrid	Body	Park Assist Module																																																															
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																																															
K	2009	Yukon Hybrid	Body	Passenger Presence System																																																															
K	2009	Yukon Hybrid	Body	Radio																																																															
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																															
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																															
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module						V																																																								
K	2009	Yukon Hybrid	Body	Rollover Sensor																																																															
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																															
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																															
K	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																															
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																				
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																															
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																													
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																		
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																		
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module										V																																																		
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																		
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW			V																																																									
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																												
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																												
K	2009	Yukon XL	Body	Amplifier (Bose)																																																												
K	2009	Yukon XL	Body	Assist Step Controller																																																												
K	2009	Yukon XL	Body	Body Control Module															V	V	V	V	V	V	V																																						
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																												
K	2009	Yukon XL	Body	Digital Radio Receiver																																																												
K	2009	Yukon XL	Body	Driver Door Switch																																																												
K	2009	Yukon XL	Body	HVAC Control Module Auto																																																												
K	2009	Yukon XL	Body	HVAC Control Module Manual																																																												
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																												
K	2009	Yukon XL	Body	Left Side Object Detection Module						V																																																					
K	2009	Yukon XL	Body	Lift Gate Module																									V	V																																		
K	2009	Yukon XL	Body	Memory Seat Module																																																												
K	2009	Yukon XL	Body	Park Assist Module																																																												
K	2009	Yukon XL	Body	Passenger Door Switch																																																												
K	2009	Yukon XL	Body	Passenger Presence System																																																												
K	2009	Yukon XL	Body	Radio																																																												
K	2009	Yukon XL	Body	Rear Heated Seat Module																																																												
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																												
K	2009	Yukon XL	Body	Right Side Object Detection Module						V																																																					
K	2009	Yukon XL	Body	Rollover Sensor																																																												
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
K	2009	Yukon XL	Body	Theft Deterrent Module																																																												
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																												
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES			V																																																							
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2010	Sierra	Chassis	Electronic Suspension Control																																																										
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra	Body	Amplifier (Bose)																																																										
K	2010	Sierra	Body	Body Control Module															V	V	V	V	V	V	V																																					
K	2010	Sierra	Body	Body Control Module (aux.)																																																										
K	2010	Sierra	Body	Digital Radio Receiver																																																										
K	2010	Sierra	Body	Driver Door Switch																																																										
K	2010	Sierra	Body	HVAC Control Module Auto																																																										
K	2010	Sierra	Body	HVAC Control Module Manual																																																										
K	2010	Sierra	Body	Instrument Panel Cluster																																																										
K	2010	Sierra	Body	Memory Seat Module																																																										
K	2010	Sierra	Body	Park Assist Module																																																										
K	2010	Sierra	Body	Passenger Door Switch																																																										
K	2010	Sierra	Body	Passenger Presence System																																																										
K	2010	Sierra	Body	Radio																																																										
K	2010	Sierra	Body	Rear Heated Seat Module																																																										
K	2010	Sierra	Body	Rear HVAC/RSA																																																										
K	2010	Sierra	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
K	2010	Sierra	Body	Theft Deterrent Module																																																										
K	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																										

| Engine type | Year | Model | System 1 | System 2 | New Actuator Setup Procedure | VSCM Data | Signal Data | VSCM Disable Reason | VSCM Power Steering Reset | Range Measurements | Module Data | Inhibit Data | Calibrate Module | Exh. Aftertreatment Data | Parking Brake Shoe Service Reset | Parking Brake Actuator DTC Reset | Parking Brake Switch Procedure | Charging Info | RVS Disable 1 History | RVS Disable 2 History | RVS Disable 3 History | RVS Disable 4 History | RVS Disable 5 History | RVS Disable 6 History | RVS Disable 7 History | Passenger presence system learn | Signal Type | Module ID Information | Open History Data | Close History Data | Last Open Fail Data | Last Close Fail Data | Obstacle Detect Opening Data | Obstacle Detect Closing Data | LGM Open/Close Test | Deployment Loop 1-14 Resistance | Deployment Loop 15-18 Resistance | Deployment Loop Configuration | Sensor Configuration | Parking Brake Calibration | CAN Bus Communication | Remote Vehicle Start Data | Remote Vehicle Start Disable History 1 Data | Remote Vehicle Start Disable History 2 Data | Remote Vehicle Start Disable History 3 Data | Remote Vehicle Start Disable History 4 Data | Remote Vehicle Start Disable History 5 Data | Remote Vehicle Start Disable History 6 Data | Remote Vehicle Start Disable History 7 Data | Steering Wheel Control Switches | Vehicle Access | Passenger Presence Data | HVAC Door Position Data | A/C Permission Data | Last Liftgate Close Malfunction Data | Last Liftgate Open Malfunction Data | Engineering Data 1 | Engineering Data 2 | Seat Position Data | Steering Column Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2010	Yukon	Body	Instrument Panel Cluster																																																														
K	2010	Yukon	Body	Left Side Object Detection Module						V																																																							
K	2010	Yukon	Body	Lift Gate Module																								V	V			V	V																																	
K	2010	Yukon	Body	Memory Seat Module																																																													
K	2010	Yukon	Body	Park Assist Module																																																													
K	2010	Yukon	Body	Passenger Door Switch																																																													
K	2010	Yukon	Body	Passenger Presence System																																																													
K	2010	Yukon	Body	Radio																																																													
K	2010	Yukon	Body	Rear Heated Seat Module																																																													
K	2010	Yukon	Body	Rear HVAC/RSA																																																													
K	2010	Yukon	Body	Right Side Object Detection Module						V																																																							
K	2010	Yukon	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
K	2010	Yukon	Body	Theft Deterrent Module																																																													
K	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																													
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																													
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																													
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																													
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																													
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																													
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																													
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																													
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																													
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																													
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																													
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																													
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																													
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																													
K	2010	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																							
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																													
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																													
K	2010	Yukon Hybrid	Body	Driver Door Switch																																																													
K	2010	Yukon Hybrid	Body	Heated Seat Module																																																													
K	2010	Yukon Hybrid	Body	HVAC Control Module																																																													
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																													
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module						V																																																							
K	2010	Yukon Hybrid	Body	Lift Gate Module																								V	V			V	V																																	
K	2010	Yukon Hybrid	Body	Park Assist Module																																																													
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																																													
K	2010	Yukon Hybrid	Body	Passenger Presence System																																																													
K	2010	Yukon Hybrid	Body	Radio																																																													
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																													
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																													
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module						V																																																							
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																													
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																													
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																																			
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																													
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																													
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																		
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																													
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																													
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																													
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																													
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																													
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																													
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW			V																																																										
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																														
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																														
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																														
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																														
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																														
K	2010	Yukon XL	Body	Amplifier (Bose)																																																														
K	2010	Yukon XL	Body	Assist Step Controller																																																														
K	2010	Yukon XL	Body	Body Control Module															V	V	V	V	V	V	V																																								
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																														
K	2010	Yukon XL	Body	Digital Radio Receiver																																																														
K	2010	Yukon XL	Body	Driver Door Switch																																																														
K	2010	Yukon XL	Body	HVAC Control Module Auto																																																														
K	2010	Yukon XL	Body	HVAC Control Module Manual																																																														
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																														
K	2010	Yukon XL	Body	Left Side Object Detection Module						V																																																							
K	2010	Yukon XL	Body	Lift Gate Module																									V	V			V	V																																
K	2010	Yukon XL	Body	Memory Seat Module																																																														
K	2010	Yukon XL	Body	Park Assist Module																																																														
K	2010	Yukon XL	Body	Passenger Door Switch																																																														
K	2010	Yukon XL	Body	Passenger Presence System																																																														
K	2010	Yukon XL	Body	Radio																																																														
K	2010	Yukon XL	Body	Rear Heated Seat Module																																																														
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																														
K	2010	Yukon XL	Body	Right Side Object Detection Module						V																																																							
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
K	2010	Yukon XL	Body	Theft Deterrent Module																																																														
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																														
L	2004	ALL	Chassis	4WAL 3 Sensor																																																														
L	2004	ALL	Body	Body Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2004	ALL	Body	Instrument Panel Cluster																																																										
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2005	ALL	Chassis	4WAL 3 Sensor																																																										
L	2005	ALL	Body	Body Control Module																																																										
L	2005	ALL	Body	Instrument Panel Cluster																																																										
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																										
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																										
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																										
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2010	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2010	Terrain	Body	Body Control Module																																																										
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2010	Terrain	Body	Passenger Presence Module																																																										
L	2010	Terrain	Body	Instrument Cluster																																																										
L	2010	Terrain	Body	Radio																																																										
L	2010	Terrain	Body	Multimedia Player Interface Module																																																										
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																																										
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																																									V						
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2010	Terrain	Body	Liftgate Control Module																																																										V	V	V	V		
L	2010	Terrain	Body	Parking Assist Control Module																																																										
L	2010	Terrain	Body	Frontview Camera Module																																																										
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																																										
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																																										
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																										
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																										
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2011	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2011	Terrain	Body	Body Control Module																																																										
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2011	Terrain	Body	Passenger Presence Module																																																										
L	2011	Terrain	Body	Instrument Cluster																																																										
L	2011	Terrain	Body	Radio																																																										
L	2011	Terrain	Body	Multimedia Player Interface Module																																																										
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																																									V						

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2011	Terrain	Body	Liftgate Control Module																																																					V	V	V	V		
L	2011	Terrain	Body	Parking Assist Control Module																																																											
L	2011	Terrain	Body	Frontview Camera Module																																																												
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																												
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2012	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2012	Terrain	Body	Body Control Module																																																												
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2012	Terrain	Body	Passenger Presence Module																																																												
L	2012	Terrain	Body	Instrument Cluster																																																												
L	2012	Terrain	Body	Radio																																																											
L	2012	Terrain	Body	Multimedia Player Interface Module																																																											
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																																				V							
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2012	Terrain	Body	Liftgate Control Module																																																				V	V	V	V		
L	2012	Terrain	Body	Parking Assist Control Module																																																											
L	2012	Terrain	Body	Frontview Camera Module																																																											
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																																											
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2013	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2013	Terrain	Chassis	Power Steering Control Module																																																											
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																																											
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2013	Terrain	Body	Passenger Presence Module																																																											
L	2013	Terrain	Body	Instrument Cluster																																																											
L	2013	Terrain	Body	Radio																																																											
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																																				V							
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2013	Terrain	Body	Liftgate Control Module																																																				V	V	V	V		
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2013	Terrain	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2013	Terrain	Body	Frontview Camera Module																																																													
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																													
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																													
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																													
L	2014	Terrain	Chassis	Electronic Brake Control Module																																																													
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																													
L	2014	Terrain	Chassis	Power Steering Control Module																																																													
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																													
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																																													
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																													
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
L	2014	Terrain	Body	Passenger Presence Module																																																													
L	2014	Terrain	Body	Instrument Cluster																																																													
L	2014	Terrain	Body	Radio																																																												
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2014	Terrain	Body	Liftgate Control Module																																																												
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																												
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																												
L	2014	Terrain	Body	Parking Assist Control Module																																																												
L	2014	Terrain	Body	Frontview Camera Module																																																												
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2015	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2015	Terrain	Chassis	Power Steering Control Module																																																												
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																																												
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2015	Terrain	Body	Passenger Presence Module																																																											
L	2015	Terrain	Body	Instrument Cluster																																																											
L	2015	Terrain	Body	Radio																																																											
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																																											
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2015	Terrain	Body	Liftgate Control Module																																																											
L	2015	Terrain	Body	Seat Memory Control Module																																																											
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2015	Terrain	Body	Parking Assist Control Module																																																											
L	2015	Terrain	Body	Frontview Camera Module																																																											
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																													
L	2016	Terrain	Chassis	Electronic Brake Control Module																																																													
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																													
L	2016	Terrain	Chassis	Power Steering Control Module																																																													
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																													
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																																													
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																													
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
L	2016	Terrain	Body	Passenger Presence Module																																																													
L	2016	Terrain	Body	Instrument Cluster																																																													
L	2016	Terrain	Body	Radio																																																													
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																																													
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																													
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																																				V								
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																																													
L	2016	Terrain	Body	Liftgate Control Module																																																						V	V	V	V				
L	2016	Terrain	Body	Seat Memory Control Module																																																													
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																													
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																													
L	2016	Terrain	Body	Parking Assist Control Module																																																													
L	2016	Terrain	Body	Frontview Camera Module																																																													
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
M	2004	ALL	Chassis	4WAL 3 Sensor																																																													
M	2004	ALL	Body	Body Control Module																																																													
M	2004	ALL	Body	Instrument Panel Cluster																																																													
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																													
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
M	2005	ALL	Chassis	4WAL 3 Sensor																																																													
M	2005	ALL	Body	Body Control Module																																																													
M	2005	ALL	Body	Instrument Panel Cluster																																																													
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																													
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																													
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																													
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																													
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																													
P	2007	ALL	Body	Theft Deterrent Module																																																													
R	2007	ALL	Powertrain	Engine Control Module																																																													
R	2007	ALL	Powertrain	Transmission Control Module																																																													
R	2007	ALL	Chassis	Electronic Brake Control Module			V																																																									
R	2007	ALL	Body	Body Control Module																																																												
R	2007	ALL	Body	Digital Radio Receiver																																																												
R	2007	ALL	Body	Driver Door Switch																																																												
R	2007	ALL	Body	Head Up Display																																																												
R	2007	ALL	Body	Heated Seat Module																																																												
R	2007	ALL	Body	HVAC Control Module Auto																																																												
R	2007	ALL	Body	HVAC Control Module Manual																																																												
R	2007	ALL	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2007	ALL	Body	Lift Gate Module																									V	V																																			
R	2007	ALL	Body	Park Assist Module																																																												
R	2007	ALL	Body	Passenger Door Switch																																																												
R	2007	ALL	Body	Passenger Presence System																																																												
R	2007	ALL	Body	Radio																																																												
R	2007	ALL	Body	Rear HVAC/RSA																																																												
R	2007	ALL	Body	Rollover Sensor																																																												
R	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2007	ALL	Body	Theft Deterrent Module																																																												
R	2008	ALL	Powertrain	Engine Control Module																																																												
R	2008	ALL	Powertrain	Transmission Control Module																																																												
R	2008	ALL	Chassis	Electronic Brake Control Module			V																																																									
R	2008	ALL	Body	Body Control Module																																																												
R	2008	ALL	Body	Digital Radio Receiver																																																												
R	2008	ALL	Body	Driver Door Switch																																																												
R	2008	ALL	Body	Head Up Display																																																												
R	2008	ALL	Body	Heated Seat Module																																																												
R	2008	ALL	Body	HVAC Control Module Auto																																																												
R	2008	ALL	Body	HVAC Control Module Manual																																																												
R	2008	ALL	Body	Instrument Panel Cluster																																																												
R	2008	ALL	Body	Lift Gate Module																									V	V																																			
R	2008	ALL	Body	Park Assist Module																																																												
R	2008	ALL	Body	Passenger Door Switch																																																												
R	2008	ALL	Body	Passenger Presence System																																																												
R	2008	ALL	Body	Radio																																																												
R	2008	ALL	Body	Rear HVAC/RSA																																																												
R	2008	ALL	Body	Rollover Sensor																																																												
R	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2008	ALL	Body	Theft Deterrent Module																																																												
R	2009	ALL	Powertrain	Engine Control Module																																																												
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2009	ALL	Powertrain	Transmission Control Module																																																												
R	2009	ALL	Chassis	Electronic Brake Control Module			V																																																									
R	2009	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																						
R	2009	ALL	Body	Digital Radio Receiver																																																												
R	2009	ALL	Body	Driver Door Switch																																																												
R	2009	ALL	Body	Head Up Display																																																												
R	2009	ALL	Body	Heated Seat Module																																																												
R	2009	ALL	Body	HVAC Control Module Auto																																																												
R	2009	ALL	Body	HVAC Control Module Manual																																																												
R	2009	ALL	Body	Instrument Panel Cluster																																																												
R	2009	ALL	Body	Lift Gate Module																									V	V			V	V																															
R	2009	ALL	Body	Park Assist Module																																																												
R	2009	ALL	Body	Passenger Door Switch																																																												
R	2009	ALL	Body	Passenger Presence System																						V																																						
R	2009	ALL	Body	Radio																																																												
R	2009	ALL	Body	Rear HVAC/RSA																																																												
R	2009	ALL	Body	Rollover Sensor																																																												
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2009	ALL	Body	Theft Deterrent Module																																																												
R	2010	ALL	Powertrain	Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																													
R	2010	ALL	Powertrain	Transmission Control Module																																																													
R	2010	ALL	Chassis	Electronic Brake Control Module			V																																																									
R	2010	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
R	2010	ALL	Body	Digital Radio Receiver																																																													
R	2010	ALL	Body	Driver Door Switch																																																													
R	2010	ALL	Body	Head Up Display																																																													
R	2010	ALL	Body	Heated Seat Module																																																													
R	2010	ALL	Body	HVAC Control Module Auto																																																													
R	2010	ALL	Body	HVAC Control Module Manual																																																													
R	2010	ALL	Body	Instrument Panel Cluster																																																													
R	2010	ALL	Body	Lift Gate Module																									V	V			V	V																																
R	2010	ALL	Body	Park Assist Module																																																													
R	2010	ALL	Body	Passenger Door Switch																																																													
R	2010	ALL	Body	Passenger Presence System																						V																																								
R	2010	ALL	Body	Radio																																																													
R	2010	ALL	Body	Rear HVAC/RSA																																																													
R	2010	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
R	2010	ALL	Body	Theft Deterrent Module																																																													
R	2011	ALL	Powertrain	Engine Control Module																																																														
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																													
R	2011	ALL	Powertrain	Transmission Control Module																																																													
R	2011	ALL	Chassis	Electronic Brake Control Module			V																																																									
R	2011	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
R	2011	ALL	Body	Digital Radio Receiver																																																													
R	2011	ALL	Body	Driver Door Switch																																																													
R	2011	ALL	Body	Head Up Display																																																													
R	2011	ALL	Body	Heated Seat Module																																																													
R	2011	ALL	Body	HVAC Control Module Auto																																																													
R	2011	ALL	Body	HVAC Control Module Manual																																																													
R	2011	ALL	Body	Instrument Panel Cluster																																																													
R	2011	ALL	Body	Lift Gate Module																									V	V			V	V																																
R	2011	ALL	Body	Park Assist Module																																																													
R	2011	ALL	Body	Passenger Door Switch																																																													
R	2011	ALL	Body	Passenger Presence System																						V																																								
R	2011	ALL	Body	Radio																																																													
R	2011	ALL	Body	Rear HVAC/RSA																																																													
R	2011	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
R	2011	ALL	Body	Theft Deterrent Module																																																													
R	2012	ALL	Powertrain	Engine Control Module										V																																																			
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																													
R	2012	ALL	Powertrain	Transmission Control Module																																																														
R	2012	ALL	Chassis	Electronic Brake Control Module			V																																																									
R	2012	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
R	2012	ALL	Body	Digital Radio Receiver																																																													
R	2012	ALL	Body	Driver Door Switch																																																													
R	2012	ALL	Body	Head Up Display																																																													
R	2012	ALL	Body	Heated Seat Module																																																													
R	2012	ALL	Body	HVAC Control Module Auto																																																													
R	2012	ALL	Body	HVAC Control Module Manual																																																													
R	2012	ALL	Body	Instrument Panel Cluster																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2012	ALL	Body	Lift Gate Module																									V	V			V	V																										
R	2012	ALL	Body	Park Assist Module																																																							
R	2012	ALL	Body	Passenger Door Switch																																																							
R	2012	ALL	Body	Passenger Presence System																					V																																			
R	2012	ALL	Body	Radio																																																							
R	2012	ALL	Body	Rear HVAC/RSA																																																							
R	2012	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																					
R	2012	ALL	Body	Theft Deterrent Module																																																							
R	2013	ALL	Powertrain	Engine Control Module										V																																														
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2013	ALL	Powertrain	Transmission Control Module																																																							
R	2013	ALL	Chassis	Electronic Brake Control Module			V																																																				
R	2013	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																			
R	2013	ALL	Body	Digital Radio Receiver																																																							
R	2013	ALL	Body	Driver Door Switch																																																							
R	2013	ALL	Body	Head Up Display																																																							
R	2013	ALL	Body	Heated Seat Module																																																							
R	2013	ALL	Body	HVAC Control Module Auto																																																							
R	2013	ALL	Body	HVAC Control Module Manual																																																							
R	2013	ALL	Body	Instrument Panel Cluster																																																							
R	2013	ALL	Body	Left Side Object Detection Module																																																							
R	2013	ALL	Body	Lift Gate Module																									V	V			V	V																											
R	2013	ALL	Body	Park Assist Module																																																							
R	2013	ALL	Body	Passenger Door Switch																																																							
R	2013	ALL	Body	Passenger Presence System																					V																																			
R	2013	ALL	Body	Radio																																																							
R	2013	ALL	Body	Rear HVAC/RSA																																																							
R	2013	ALL	Body	Right Side Object Detection Module																																																							
R	2013	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																					
R	2013	ALL	Body	Theft Deterrent Module																																																							
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																							
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																							
R	2014	Acadia	Powertrain	Chassis Control Module																																																							
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																							
R	2014	Acadia	Chassis	Electronic Brake Control Module																																																							
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																			V	V	V	V	V	V	V	V	V	V											
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																			V	V	V	V	V	V	V	V	V	V											
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
R	2014	Acadia	Body	Passenger Presence Module																																														V									
R	2014	Acadia	Body	Instrument Cluster																																																						
R	2014	Acadia	Body	Head-Up Display Module																																																						
R	2014	Acadia	Body	Radio																																																						
R	2014	Acadia	Body	Rear Audio Control Module																																																						
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																						
R	2014	Acadia	Body	Personal Audio Link Control Module																																																						
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																						
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																						
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																															V							
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																															V							
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																						
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																						

| Engine type | Year | Model | System 1 | System 2 | New Actuator Setup Procedure | VSCM Data | Signal Data | VSCM Disable Reason | VSCM Power Steering Reset | Range Measurements | Module Data | Inhibit Data | Calibrate Module | Exh. Aftertreatment Data | Parking Brake Shoe Service Reset | Parking Brake Actuator DTC Reset | Parking Brake Switch Procedure | Charging Info | RVS Disable 1 History | RVS Disable 2 History | RVS Disable 3 History | RVS Disable 4 History | RVS Disable 5 History | RVS Disable 6 History | RVS Disable 7 History | Passenger presence system learn | Signal Type | Module ID Information | Open History Data | Close History Data | Last Open Fail Data | Last Close Fail Data | Obstacle Detect Opening Data | Obstacle Detect Closing Data | LGM Open/Close Test | Deployment Loop 1-14 Resistance | Deployment Loop 15-18 Resistance | Deployment Loop Configuration | Sensor Configuration | Parking Brake Calibration | CAN Bus Communication | Remote Vehicle Start Data | Remote Vehicle Start Disable History 1 Data | Remote Vehicle Start Disable History 2 Data | Remote Vehicle Start Disable History 3 Data | Remote Vehicle Start Disable History 4 Data | Remote Vehicle Start Disable History 5 Data | Remote Vehicle Start Disable History 6 Data | Remote Vehicle Start Disable History 7 Data | Steering Wheel Control Switches | Vehicle Access | Passenger Presence Data | HVAC Door Position Data | A/C Permission Data | Last Liftgate Close Malfunction Data | Last Liftgate Open Malfunction Data | Engineering Data 1 | Engineering Data 2 | Seat Position Data | Steering Column Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
R	2016	Acadia	Body	Personal Audio Link Control Module																																																															
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																															
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																		V											
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																		V											
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																													
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																													
R	2016	Acadia	Body	Liftgate Control Module																																																						V	V	V	V			
R	2016	Acadia	Body	Seat Memory Control Module																																																										V	V
R	2016	Acadia	Body	Front Seat Heating Control Module																																																													
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																													
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																													
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																													
R	2016	Acadia	Body	Parking Assist Control Module																																																													
R	2016	Acadia	Body	Frontview Camera Module																																																													
R	2016	Acadia	Body	Theft Deterrent Module																																																													
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																													
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																													
S	2004	Sonoma	Body	Body Control Module																																																													
S	2004	Sonoma	Body	Instrument Panel Cluster																																																													
S	2004	Sonoma	Body	Base Radio																																																													
S	2004	Sonoma	Body	Uplevel Radio																																																													
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																													
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																													
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																													
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																													
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																													
S	2004	Canyon	Chassis	ABS Without Traction Control																																																													
S	2004	Canyon	Chassis	ABS With Traction Control																																																													
S	2004	Canyon	Body	Body Control Module																																																													
S	2004	Canyon	Body	Instrument Panel Cluster																																																													
S	2004	Canyon	Body	OnStar																																																													
S	2004	Canyon	Body	Base Radio																																																													
S	2004	Canyon	Body	Uplevel Radio																																																													
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																																													
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
S	2004	Envoy	Chassis	ABS Without Traction Control																																																													
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																													
S	2004	Envoy	Body	Amplifier (Bose)																																																													
S	2004	Envoy	Body	Body Control Module																																																													
S	2004	Envoy	Body	Driver Door Module																																																													
S	2004	Envoy	Body	Driver Seat Module																																																													
S	2004	Envoy	Body	Heating and Air Conditioning Auto																																																													
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																													
S	2004	Envoy	Body	Instrument Panel Cluster																																																													
S	2004	Envoy	Body	Lift Gate Module																																																													
S	2004	Envoy	Body	OnStar																																																													
S	2004	Envoy	Body	Passenger Door Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2004	Envoy	Body	Uplevel Radio																																																										
S	2004	Envoy	Body	Navigation Radio																																																										
S	2004	Envoy	Body	Rear Seat Audio																																																										
S	2004	Envoy	Body	Rear Seat Entertainment																																																										
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy XL	Body	Amplifier (Bose)																																																										
S	2004	Envoy XL	Body	Body Control Module																																																										
S	2004	Envoy XL	Body	Driver Door Module																																																										
S	2004	Envoy XL	Body	Driver Seat Module																																																										
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																										
S	2004	Envoy XL	Body	Lift Gate Module																																																										
S	2004	Envoy XL	Body	OnStar																																																										
S	2004	Envoy XL	Body	Passenger Door Module																																																										
S	2004	Envoy XL	Body	Uplevel Radio																																																										
S	2004	Envoy XL	Body	Navigation Radio																																																										
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
S	2004	Envoy XL	Body	Rear HVAC Manual																																																										
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																										
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																										
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																										
S	2004	Envoy XUV	Body	Body Control Module																																																										
S	2004	Envoy XUV	Body	Driver Door Module																																																										
S	2004	Envoy XUV	Body	Driver Seat Module																																																										
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																										
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																										
S	2004	Envoy XUV	Body	Lift Gate Module																																																										
S	2004	Envoy XUV	Body	OnStar																																																										
S	2004	Envoy XUV	Body	Passenger Door Module																																																										
S	2004	Envoy XUV	Body	Uplevel Radio																																																										
S	2004	Envoy XUV	Body	Navigation Radio																																																										
S	2004	Envoy XUV	Body	Rear Seat Audio																																																										
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																										
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Jimmy	Body	Body Control Module																																																										
S	2004	Jimmy	Body	Heating and Air Conditioning																																																										
S	2004	Jimmy	Body	Instrument Panel Cluster																																																										
S	2004	Jimmy	Body	Memory Seat Module																																																										
S	2004	Jimmy	Body	Base Radio																																																										
S	2004	Jimmy	Body	Uplevel Radio																																																										
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2005	Canyon	Chassis	ABS Without Traction Control																																																										
S	2005	Canyon	Chassis	ABS With Traction Control																																																										
S	2005	Canyon	Body	Body Control Module																																																										
S	2005	Canyon	Body	Instrument Panel Cluster																																																										
S	2005	Canyon	Body	Base Radio																																																										
S	2005	Canyon	Body	Uplevel Radio																																																										
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy	Body	Body Control Module																																																										
S	2005	Envoy	Body	Disc Player and Video Display																																																										
S	2005	Envoy	Body	Driver Door Module																																																										
S	2005	Envoy	Body	Driver Seat Module																																																										
S	2005	Envoy	Body	Heating and Air Conditioning Auto																																																										
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy	Body	Instrument Panel Cluster																																																										
S	2005	Envoy	Body	Lift Gate Module																																																										
S	2005	Envoy	Body	Passenger Door Module																																																										
S	2005	Envoy	Body	Passenger Presence System																																																										
S	2005	Envoy	Body	Uplevel Radio																																																										
S	2005	Envoy	Body	Navigation Radio																																																										
S	2005	Envoy	Body	Rear Seat Audio																																																										
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																														
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																														
S	2005	Envoy XL	Body	Body Control Module																																																														
S	2005	Envoy XL	Body	Disc Player and Video Display																																																														
S	2005	Envoy XL	Body	Driver Door Module																																																														
S	2005	Envoy XL	Body	Driver Seat Module																																																														
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																														
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																														
S	2005	Envoy XL	Body	Instrument Panel Cluster																																																														
S	2005	Envoy XL	Body	Lift Gate Module																																																														
S	2005	Envoy XL	Body	Passenger Door Module																																																														
S	2005	Envoy XL	Body	Passenger Presence System																																																														
S	2005	Envoy XL	Body	Uplevel Radio																																																														
S	2005	Envoy XL	Body	Navigation Radio																																																														
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																														
S	2005	Envoy XL	Body	Rear HVAC Manual																																																														
S	2005	Envoy XL	Body	Rear Seat Audio																																																														
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																														
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																														
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																														
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																														
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																														
S	2005	Envoy XUV	Body	Body Control Module																																																														
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																														
S	2005	Envoy XUV	Body	Driver Door Module																																																														
S	2005	Envoy XUV	Body	Driver Seat Module																																																														
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																														
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																														
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																																														
S	2005	Envoy XUV	Body	Lift Gate Module																																																														
S	2005	Envoy XUV	Body	Passenger Door Module																																																														
S	2005	Envoy XUV	Body	Passenger Presence System																																																														
S	2005	Envoy XUV	Body	Uplevel Radio																																																														
S	2005	Envoy XUV	Body	Navigation Radio																																																														
S	2005	Envoy XUV	Body	Rear Seat Audio																																																														
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																														
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																														
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																														
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																														
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																														
S	2005	Jimmy	Body	Body Control Module																																																														
S	2005	Jimmy	Body	Heating and Air Conditioning																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2005	Jimmy	Body	Instrument Panel Cluster																																																												
S	2005	Jimmy	Body	Memory Seat Module																																																												
S	2005	Jimmy	Body	Base Radio																																																												
S	2005	Jimmy	Body	Uplevel Radio																																																												
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																												
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																												
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																												
S	2005	Sonoma	Body	Body Control Module																																																												
S	2005	Sonoma	Body	Instrument Panel Cluster																																																												
S	2005	Sonoma	Body	Base Radio																																																												
S	2005	Sonoma	Body	Uplevel Radio																																																												
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																												
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
S	2006	Canyon	Chassis	ABS Without Traction Control																																																												
S	2006	Canyon	Chassis	ABS With Traction Control																																																												
S	2006	Canyon	Body	Body Control Module																																																												
S	2006	Canyon	Body	Instrument Panel Cluster																																																												
S	2006	Canyon	Body	Passenger Presence System																																																												
S	2006	Canyon	Body	Base Radio																																																												
S	2006	Canyon	Body	Uplevel Radio																																																												
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																																												
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																																												
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2006	Envoy	Chassis	ABS/TCS/VSES																																																												
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																												
S	2006	Envoy	Body	Body Control Module																																																												
S	2006	Envoy	Body	Disc Player and Video Display																																																												
S	2006	Envoy	Body	Driver Door Module																																																												
S	2006	Envoy	Body	Driver Seat Module																																																												
S	2006	Envoy	Body	Heating and Air Conditioning Auto																																																												
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																																												
S	2006	Envoy	Body	Instrument Panel Cluster																																																												
S	2006	Envoy	Body	Lift Gate Module																																																												
S	2006	Envoy	Body	Passenger Door Module																																																												
S	2006	Envoy	Body	Passenger Presence System																																																												
S	2006	Envoy	Body	Uplevel Radio																																																												
S	2006	Envoy	Body	Navigation Radio																																																												
S	2006	Envoy	Body	Rear Seat Audio																																																												
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2006	Envoy	Body	Vehicle Theft Deterrent																																																												
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																												
S	2006	Envoy XL	Body	Body Control Module																																																												
S	2006	Envoy XL	Body	Disc Player and Video Display																																																												
S	2006	Envoy XL	Body	Driver Door Module																																																												
S	2006	Envoy XL	Body	Driver Seat Module																																																												
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
S	2006	Envoy XL	Body	Instrument Panel Cluster																																																												
S	2006	Envoy XL	Body	Lift Gate Module																																																												
S	2006	Envoy XL	Body	Passenger Door Module																																																												
S	2006	Envoy XL	Body	Passenger Presence System																																																												
S	2006	Envoy XL	Body	Uplevel Radio																																																												
S	2006	Envoy XL	Body	Navigation Radio																																																												
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
S	2006	Envoy XL	Body	Rear HVAC Manual																																																												
S	2006	Envoy XL	Body	Rear Seat Audio																																																												
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																												
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																												
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2007	Canyon	Body	Body Control Module																																																												
S	2007	Canyon	Body	Digital Radio Receiver																																																												
S	2007	Canyon	Body	Generator Battery Control Module																																																												
S	2007	Canyon	Body	Instrument Panel Cluster																																																												
S	2007	Canyon	Body	Passenger Presence System																																																												
S	2007	Canyon	Body	Base Radio																																																											
S	2007	Canyon	Body	Uplevel Radio																																																											
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																											
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2007	Envoy	Chassis	Electronic Brake Control Module																																																											
S	2007	Envoy	Body	Body Control Module																																																											
S	2007	Envoy	Body	Digital Radio Receiver																																																											
S	2007	Envoy	Body	Disc Player and Video Display																																																											
S	2007	Envoy	Body	Driver Door Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2007	Envoy	Body	Driver Seat Module																																																										
S	2007	Envoy	Body	Generator Battery Control Module																																																										
S	2007	Envoy	Body	HVAC Control Module Auto																																																										
S	2007	Envoy	Body	HVAC Control Module Manual																																																										
S	2007	Envoy	Body	Instrument Panel Cluster																																																										
S	2007	Envoy	Body	Lift Gate Module																																																										
S	2007	Envoy	Body	Passenger Door Module																																																										
S	2007	Envoy	Body	Passenger Presence System																																																										
S	2007	Envoy	Body	Uplevel Radio																																																										
S	2007	Envoy	Body	Navigation Radio																																																										
S	2007	Envoy	Body	Rear Seat Audio																																																										
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2007	Envoy	Body	Theft Deterrent Module																																																										
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																																										
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																										
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																										
S	2008	Canyon	Body	Body Control Module																																																										
S	2008	Canyon	Body	Digital Radio Receiver																																																										
S	2008	Canyon	Body	Generator Battery Control Module																																																										
S	2008	Canyon	Body	Instrument Panel Cluster																																																										
S	2008	Canyon	Body	Passenger Presence System																																																										
S	2008	Canyon	Body	Base Radio																																																										
S	2008	Canyon	Body	Uplevel Radio																																																										
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2008	Canyon	Body	Theft Deterrent Module																																																										
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2008	Envoy	Chassis	Electronic Brake Control Module																																																										
S	2008	Envoy	Body	Body Control Module																																																										
S	2008	Envoy	Body	Digital Radio Receiver																																																										
S	2008	Envoy	Body	Disc Player and Video Display																																																										
S	2008	Envoy	Body	Driver Door Module																																																										
S	2008	Envoy	Body	Driver Seat Module																																																										
S	2008	Envoy	Body	Generator Battery Control Module																																																										
S	2008	Envoy	Body	HVAC Control Module Auto																																																										
S	2008	Envoy	Body	HVAC Control Module Manual																																																										
S	2008	Envoy	Body	Instrument Panel Cluster																																																										
S	2008	Envoy	Body	Lift Gate Module																																																										
S	2008	Envoy	Body	Passenger Door Module																																																										
S	2008	Envoy	Body	Passenger Presence System																																																										
S	2008	Envoy	Body	Uplevel Radio																																																										
S	2008	Envoy	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2008	Envoy	Body	Rear Seat Audio																																																														
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																																													
S	2008	Envoy	Body	Theft Deterrent Module																																																													
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																																													
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																		
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																													
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																													
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																			
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																													
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																													
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module										V																																																			
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																													
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																													
S	2009	Canyon	Chassis	Electronic Brake Control Module																																																													
S	2009	Canyon	Body	Body Control Module																																																													
S	2009	Canyon	Body	Digital Radio Receiver																																																													
S	2009	Canyon	Body	Generator Battery Control Module																																																													
S	2009	Canyon	Body	Instrument Panel Cluster																																																													
S	2009	Canyon	Body	Passenger Presence System																																																													
S	2009	Canyon	Body	Base Radio																																																													
S	2009	Canyon	Body	Uplevel Radio																																																													
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																																													
S	2009	Canyon	Body	Theft Deterrent Module																																																													
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module										V																																																			
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																													
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																			
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																													
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module										V																																																			
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																													
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																													
S	2009	Envoy	Chassis	Electronic Brake Control Module																																																													
S	2009	Envoy	Body	Body Control Module																																																													
S	2009	Envoy	Body	Digital Radio Receiver																																																													
S	2009	Envoy	Body	Disc Player and Video Display																																																													
S	2009	Envoy	Body	Driver Door Module																																																													
S	2009	Envoy	Body	Driver Seat Module																																																													
S	2009	Envoy	Body	Generator Battery Control Module																																																													
S	2009	Envoy	Body	HVAC Control Module Auto																																																													
S	2009	Envoy	Body	HVAC Control Module Manual																																																													
S	2009	Envoy	Body	Instrument Panel Cluster																																																													
S	2009	Envoy	Body	Lift Gate Module																																																													
S	2009	Envoy	Body	Passenger Door Module																																																													
S	2009	Envoy	Body	Passenger Presence System																																																													
S	2009	Envoy	Body	Uplevel Radio																																																													
S	2009	Envoy	Body	Navigation Radio																																																													
S	2009	Envoy	Body	Rear Seat Audio																																																													
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																																													
S	2009	Envoy	Body	Theft Deterrent Module																																																													
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																			

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																	
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module										V																																																	
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
S	2010	ALL	Chassis	Electronic Brake Control Module																																																												
S	2010	ALL	Body	Body Control Module																																																											
S	2010	ALL	Body	Digital Radio Receiver																																																											
S	2010	ALL	Body	Generator Battery Control Module																																																											
S	2010	ALL	Body	Instument Panel Cluster																																																											
S	2010	ALL	Body	Passenger Presence System																																																											
S	2010	ALL	Body	Personal Audio Link Module																																																											
S	2010	ALL	Body	Base Radio																																																											
S	2010	ALL	Body	Uplevel Radio																																																											
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
S	2010	ALL	Body	Theft Deterrent Module																																																											
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																											
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																											
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																											
T	2004	Sonoma	Body	Body Control Module																																																											
T	2004	Sonoma	Body	Instrument Panel Cluster																																																											
T	2004	Sonoma	Body	Base Radio																																																											
T	2004	Sonoma	Body	Uplevel Radio																																																											
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																											
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
T	2004	Canyon	Chassis	ABS Without Traction Control																																																											
T	2004	Canyon	Chassis	ABS With Traction Control																																																											
T	2004	Canyon	Body	Body Control Module																																																											
T	2004	Canyon	Body	Instrument Panel Cluster																																																											
T	2004	Canyon	Body	OnStar																																																										
T	2004	Canyon	Body	Base Radio																																																										
T	2004	Canyon	Body	Uplevel Radio																																																										
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																																											
T	2004	Canyon	Body	Instrument Panel Cluster																																																											
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																											
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																											
T	2004	Envoy	Chassis	ABS Without Traction Control																																																											
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																											
T	2004	Envoy	Body	Amplifier (Bose)																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2004	Envoy	Body	Body Control Module																																																										
T	2004	Envoy	Body	Driver Door Module																																																										
T	2004	Envoy	Body	Driver Seat Module																																																										
T	2004	Envoy	Body	Heating and Air Conditioning Auto																																																										
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																																										
T	2004	Envoy	Body	Instrument Panel Cluster																																																										
T	2004	Envoy	Body	Lift Gate Module																																																										
T	2004	Envoy	Body	OnStar																																																										
T	2004	Envoy	Body	Passenger Door Module																																																										
T	2004	Envoy	Body	Uplevel Radio																																																										
T	2004	Envoy	Body	Navigation Radio																																																										
T	2004	Envoy	Body	Rear Seat Audio																																																										
T	2004	Envoy	Body	Rear Seat Entertainment																																																										
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy XL	Body	Amplifier (Bose)																																																										
T	2004	Envoy XL	Body	Body Control Module																																																										
T	2004	Envoy XL	Body	Driver Door Module																																																										
T	2004	Envoy XL	Body	Driver Seat Module																																																										
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2004	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2004	Envoy XL	Body	Lift Gate Module																																																										
T	2004	Envoy XL	Body	OnStar																																																										
T	2004	Envoy XL	Body	Passenger Door Module																																																										
T	2004	Envoy XL	Body	Uplevel Radio																																																										
T	2004	Envoy XL	Body	Navigation Radio																																																										
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2004	Envoy XL	Body	Rear HVAC Manual																																																										
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																										
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2004	Envoy XUV	Body	Body Control Module																																																												
T	2004	Envoy XUV	Body	Driver Door Module																																																												
T	2004	Envoy XUV	Body	Driver Seat Module																																																												
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																												
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																												
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																																												
T	2004	Envoy XUV	Body	Lift Gate Module																																																												
T	2004	Envoy XUV	Body	OnStar																																																												
T	2004	Envoy XUV	Body	Passenger Door Module																																																												
T	2004	Envoy XUV	Body	Uplevel Radio																																																												
T	2004	Envoy XUV	Body	Navigation Radio																																																												
T	2004	Envoy XUV	Body	Rear Seat Audio																																																												
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																												
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																												
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																												
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																												
T	2004	Jimmy	Body	Body Control Module																																																												
T	2004	Jimmy	Body	Heating and Air Conditioning																																																												
T	2004	Jimmy	Body	Instrument Panel Cluster																																																												
T	2004	Jimmy	Body	Memory Seat Module																																																												
T	2004	Jimmy	Body	Base Radio																																																												
T	2004	Jimmy	Body	Uplevel Radio																																																												
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																												
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2005	Canyon	Chassis	ABS Without Traction Control																																																												
T	2005	Canyon	Chassis	ABS With Traction Control																																																												
T	2005	Canyon	Body	Body Control Module																																																												
T	2005	Canyon	Body	Instrument Panel Cluster																																																												
T	2005	Canyon	Body	Base Radio																																																												
T	2005	Canyon	Body	Uplevel Radio																																																												
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																											
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																											
T	2005	Envoy	Chassis	ABS Without Traction Control																																																												
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Envoy	Body	Body Control Module																																																												
T	2005	Envoy	Body	Disc Player and Video Display																																																												
T	2005	Envoy	Body	Driver Door Module																																																												
T	2005	Envoy	Body	Driver Seat Module																																																												
T	2005	Envoy	Body	Heating and Air Conditioning Auto																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																																												
T	2005	Envoy	Body	Instrument Panel Cluster																																																												
T	2005	Envoy	Body	Lift Gate Module																																																												
T	2005	Envoy	Body	Passenger Door Module																																																												
T	2005	Envoy	Body	Passenger Presence System																																																												
T	2005	Envoy	Body	Uplevel Radio																																																												
T	2005	Envoy	Body	Navigation Radio																																																												
T	2005	Envoy	Body	Rear Seat Audio																																																												
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																																												
T	2005	Envoy	Body	Vehicle Theft Deterrent																																																												
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																												
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Envoy XL	Body	Body Control Module																																																												
T	2005	Envoy XL	Body	Disc Player and Video Display																																																												
T	2005	Envoy XL	Body	Driver Door Module																																																												
T	2005	Envoy XL	Body	Driver Seat Module																																																												
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
T	2005	Envoy XL	Body	Instrument Panel Cluster																																																												
T	2005	Envoy XL	Body	Lift Gate Module																																																												
T	2005	Envoy XL	Body	Passenger Door Module																																																												
T	2005	Envoy XL	Body	Passenger Presence System																																																												
T	2005	Envoy XL	Body	Uplevel Radio																																																												
T	2005	Envoy XL	Body	Navigation Radio																																																												
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
T	2005	Envoy XL	Body	Rear HVAC Manual																																																												
T	2005	Envoy XL	Body	Rear Seat Audio																																																												
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																												
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																												
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																												
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Envoy XUV	Body	Body Control Module																																																												
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																												
T	2005	Envoy XUV	Body	Driver Door Module																																																												
T	2005	Envoy XUV	Body	Driver Seat Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																												
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																												
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																																												
T	2005	Envoy XUV	Body	Lift Gate Module																																																												
T	2005	Envoy XUV	Body	Passenger Door Module																																																												
T	2005	Envoy XUV	Body	Passenger Presence System																																																												
T	2005	Envoy XUV	Body	Uplevel Radio																																																												
T	2005	Envoy XUV	Body	Navigation Radio																																																												
T	2005	Envoy XUV	Body	Rear Seat Audio																																																												
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																												
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																												
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																												
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																												
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Jimmy	Body	Body Control Module																																																												
T	2005	Jimmy	Body	Heating and Air Conditioning																																																												
T	2005	Jimmy	Body	Instrument Panel Cluster																																																												
T	2005	Jimmy	Body	Memory Seat Module																																																												
T	2005	Jimmy	Body	Base Radio																																																												
T	2005	Jimmy	Body	Uplevel Radio																																																												
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																												
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																												
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Sonoma	Body	Body Control Module																																																												
T	2005	Sonoma	Body	Instrument Panel Cluster																																																												
T	2005	Sonoma	Body	Base Radio																																																												
T	2005	Sonoma	Body	Uplevel Radio																																																												
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																												
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2006	Canyon	Chassis	ABS Without Traction Control																																																												
T	2006	Canyon	Chassis	ABS With Traction Control																																																												
T	2006	Canyon	Body	Body Control Module																																																												
T	2006	Canyon	Body	Instrument Panel Cluster																																																												
T	2006	Canyon	Body	Passenger Presence System																																																												
T	2006	Canyon	Body	Base Radio																																																												
T	2006	Canyon	Body	Uplevel Radio																																																												
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																																												
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2006	Envoy	Chassis	ABS/TCS/VSES																																																										
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																										
T	2006	Envoy	Body	Body Control Module																																																										
T	2006	Envoy	Body	Disc Player and Video Display																																																										
T	2006	Envoy	Body	Driver Door Module																																																										
T	2006	Envoy	Body	Driver Seat Module																																																										
T	2006	Envoy	Body	Heating and Air Conditioning Auto																																																										
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																																										
T	2006	Envoy	Body	Instrument Panel Cluster																																																										
T	2006	Envoy	Body	Lift Gate Module																																																										
T	2006	Envoy	Body	Passenger Door Module																																																										
T	2006	Envoy	Body	Passenger Presence System																																																										
T	2006	Envoy	Body	Uplevel Radio																																																										
T	2006	Envoy	Body	Navigation Radio																																																										
T	2006	Envoy	Body	Rear Seat Audio																																																										
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2006	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																										
T	2006	Envoy XL	Body	Body Control Module																																																										
T	2006	Envoy XL	Body	Disc Player and Video Display																																																										
T	2006	Envoy XL	Body	Driver Door Module																																																										
T	2006	Envoy XL	Body	Driver Seat Module																																																										
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2006	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2006	Envoy XL	Body	Lift Gate Module																																																										
T	2006	Envoy XL	Body	Passenger Door Module																																																										
T	2006	Envoy XL	Body	Passenger Presence System																																																										
T	2006	Envoy XL	Body	Uplevel Radio																																																										
T	2006	Envoy XL	Body	Navigation Radio																																																										
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2006	Envoy XL	Body	Rear HVAC Manual																																																										
T	2006	Envoy XL	Body	Rear Seat Audio																																																										
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																										
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																													
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																													
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																													
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																													
T	2007	Canyon	Body	Body Control Module																																																													
T	2007	Canyon	Body	Digital Radio Receiver																																																													
T	2007	Canyon	Body	Generator Battery Control Module																																																													
T	2007	Canyon	Body	Instrument Panel Cluster																																																													
T	2007	Canyon	Body	Passenger Presence System																																																													
T	2007	Canyon	Body	Base Radio																																																													
T	2007	Canyon	Body	Uplevel Radio																																																													
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																																													
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																																													
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																													
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																													
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																													
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																													
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																													
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																													
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																													
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																													
T	2007	Envoy	Chassis	Electronic Brake Control Module																																																													
T	2007	Envoy	Body	Body Control Module																																																													
T	2007	Envoy	Body	Digital Radio Receiver																																																													
T	2007	Envoy	Body	Disc Player and Video Display																																																													
T	2007	Envoy	Body	Driver Door Module																																																													
T	2007	Envoy	Body	Driver Seat Module																																																													
T	2007	Envoy	Body	Generator Battery Control Module																																																													
T	2007	Envoy	Body	HVAC Control Module Auto																																																													
T	2007	Envoy	Body	HVAC Control Module Manual																																																													
T	2007	Envoy	Body	Instrument Panel Cluster																																																													
T	2007	Envoy	Body	Lift Gate Module																																																													
T	2007	Envoy	Body	Passenger Door Module																																																													
T	2007	Envoy	Body	Passenger Presence System																																																													
T	2007	Envoy	Body	Uplevel Radio																																																													
T	2007	Envoy	Body	Navigation Radio																																																													
T	2007	Envoy	Body	Rear Seat Audio																																																													
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																																													
T	2007	Envoy	Body	Theft Deterrent Module																																																													
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																																													
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																													
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																													
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																													
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																													
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																													
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																													
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2008	Canyon	Body	Body Control Module																																																															
T	2008	Canyon	Body	Digital Radio Receiver																																																															
T	2008	Canyon	Body	Generator Battery Control Module																																																															
T	2008	Canyon	Body	Instrument Panel Cluster																																																															
T	2008	Canyon	Body	Passenger Presence System																																																															
T	2008	Canyon	Body	Base Radio																																																															
T	2008	Canyon	Body	Uplevel Radio																																																															
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																																															
T	2008	Canyon	Body	Theft Deterrent Module																																																															
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																																															
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																															
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																															
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
T	2008	Envoy	Chassis	Electronic Brake Control Module																																																															
T	2008	Envoy	Body	Body Control Module																																																															
T	2008	Envoy	Body	Digital Radio Receiver																																																															
T	2008	Envoy	Body	Disc Player and Video Display																																																															
T	2008	Envoy	Body	Driver Door Module																																																															
T	2008	Envoy	Body	Driver Seat Module																																																															
T	2008	Envoy	Body	Generator Battery Control Module																																																															
T	2008	Envoy	Body	HVAC Control Module Auto																																																															
T	2008	Envoy	Body	HVAC Control Module Manual																																																															
T	2008	Envoy	Body	Instrument Panel Cluster																																																															
T	2008	Envoy	Body	Lift Gate Module																																																															
T	2008	Envoy	Body	Passenger Door Module																																																															
T	2008	Envoy	Body	Passenger Presence System																																																															
T	2008	Envoy	Body	Uplevel Radio																																																															
T	2008	Envoy	Body	Navigation Radio																																																															
T	2008	Envoy	Body	Rear Seat Audio																																																															
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																																															
T	2008	Envoy	Body	Theft Deterrent Module																																																															
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																																															
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																					
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																															
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																					
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																															
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module										V																																																					
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																															
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																															
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																															
T	2009	Canyon	Chassis	Electronic Brake Control Module																																																															
T	2009	Canyon	Body	Body Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2009	Canyon	Body	Digital Radio Receiver																																																											
T	2009	Canyon	Body	Generator Battery Control Module																																																											
T	2009	Canyon	Body	Instrument Panel Cluster																																																											
T	2009	Canyon	Body	Passenger Presence System																																																											
T	2009	Canyon	Body	Base Radio																																																											
T	2009	Canyon	Body	Uplevel Radio																																																											
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																																											
T	2009	Canyon	Body	Theft Deterrent Module																																																											
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module										V																																																	
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																	
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module										V																																																	
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																												
T	2009	Envoy	Body	Body Control Module																																																											
T	2009	Envoy	Body	Digital Radio Receiver																																																											
T	2009	Envoy	Body	Disc Player and Video Display																																																											
T	2009	Envoy	Body	Driver Door Module																																																											
T	2009	Envoy	Body	Driver Seat Module																																																											
T	2009	Envoy	Body	Generator Battery Control Module																																																											
T	2009	Envoy	Body	HVAC Control Module Auto																																																											
T	2009	Envoy	Body	HVAC Control Module Manual																																																											
T	2009	Envoy	Body	Instrument Panel Cluster																																																											
T	2009	Envoy	Body	Lift Gate Module																																																											
T	2009	Envoy	Body	Passenger Door Module																																																											
T	2009	Envoy	Body	Passenger Presence System																																																											
T	2009	Envoy	Body	Uplevel Radio																																																											
T	2009	Envoy	Body	Navigation Radio																																																											
T	2009	Envoy	Body	Rear Seat Audio																																																											
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																																											
T	2009	Envoy	Body	Theft Deterrent Module																																																											
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																	
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																	
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module										V																																																	
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
T	2010	ALL	Chassis	Electronic Brake Control Module																																																											
T	2010	ALL	Body	Body Control Module																																																											
T	2010	ALL	Body	Digital Radio Receiver																																																											
T	2010	ALL	Body	Generator Battery Control Module																																																											
T	2010	ALL	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
T	2010	ALL	Body	Passenger Presence System																																																														
T	2010	ALL	Body	Personal Audio Link Module																																																														
T	2010	ALL	Body	Base Radio																																																														
T	2010	ALL	Body	Uplevel Radio																																																														
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																														
T	2010	ALL	Body	Theft Deterrent Module																																																														
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																														
V	2007	ALL	Powertrain	Engine Control Module																																																														
V	2007	ALL	Powertrain	Rear Drive System																																																														
V	2007	ALL	Powertrain	Transmission Control Module																																																														
V	2007	ALL	Chassis	Electronic Brake Control Module			V																																																										
V	2007	ALL	Body	Body Control Module																																																														
V	2007	ALL	Body	Digital Radio Receiver																																																														
V	2007	ALL	Body	Driver Door Switch																																																														
V	2007	ALL	Body	Head Up Display																																																														
V	2007	ALL	Body	Heated Seat Module																																																														
V	2007	ALL	Body	HVAC Control Module Auto																																																														
V	2007	ALL	Body	HVAC Control Module Manual																																																														
V	2007	ALL	Body	Instrument Panel Cluster																																																														
V	2007	ALL	Body	Lift Gate Module																									V	V																																				
V	2007	ALL	Body	Park Assist Module																																																														
V	2007	ALL	Body	Passenger Door Switch																																																														
V	2007	ALL	Body	Passenger Presence System																																																														
V	2007	ALL	Body	Radio																																																														
V	2007	ALL	Body	Rear HVAC/RSA																																																														
V	2007	ALL	Body	Rollover Sensor																																																														
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2007	ALL	Body	Theft Deterrent Module																																																														
V	2008	ALL	Powertrain	Engine Control Module																																																														
V	2008	ALL	Powertrain	Rear Drive System																																																														
V	2008	ALL	Powertrain	Transmission Control Module																																																														
V	2008	ALL	Chassis	Electronic Brake Control Module			V																																																										
V	2008	ALL	Body	Body Control Module																																																														
V	2008	ALL	Body	Digital Radio Receiver																																																														
V	2008	ALL	Body	Driver Door Switch																																																														
V	2008	ALL	Body	Head Up Display																																																														
V	2008	ALL	Body	Heated Seat Module																																																														
V	2008	ALL	Body	HVAC Control Module Auto																																																														
V	2008	ALL	Body	HVAC Control Module Manual																																																														
V	2008	ALL	Body	Instrument Panel Cluster																																																														
V	2008	ALL	Body	Lift Gate Module																									V	V																																				
V	2008	ALL	Body	Park Assist Module																																																														
V	2008	ALL	Body	Passenger Door Switch																																																														
V	2008	ALL	Body	Passenger Presence System																																																														
V	2008	ALL	Body	Radio																																																														
V	2008	ALL	Body	Rear HVAC/RSA																																																														
V	2008	ALL	Body	Rollover Sensor																																																														
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2008	ALL	Body	Theft Deterrent Module																																																														
V	2009	ALL	Powertrain	Engine Control Module																																																															
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																														

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
V	2009	ALL	Powertrain	Rear Drive System																																																													
V	2009	ALL	Powertrain	Transmission Control Module																																																													
V	2009	ALL	Chassis	Electronic Brake Control Module			V																																																									
V	2009	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
V	2009	ALL	Body	Digital Radio Receiver																																																													
V	2009	ALL	Body	Driver Door Switch																																																													
V	2009	ALL	Body	Head Up Display																																																													
V	2009	ALL	Body	Heated Seat Module																																																													
V	2009	ALL	Body	HVAC Control Module Auto																																																													
V	2009	ALL	Body	HVAC Control Module Manual																																																													
V	2009	ALL	Body	Instrument Panel Cluster																																																													
V	2009	ALL	Body	Lift Gate Module																									V	V			V	V																																
V	2009	ALL	Body	Park Assist Module																																																												
V	2009	ALL	Body	Passenger Door Switch																																																													
V	2009	ALL	Body	Passenger Presence System																						V																																								
V	2009	ALL	Body	Radio																																																													
V	2009	ALL	Body	Rear HVAC/RSA																																																													
V	2009	ALL	Body	Rollover Sensor																																																													
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																													
V	2009	ALL	Body	Theft Deterrent Module																																																													
V	2010	ALL	Powertrain	Engine Control Module																																																														
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																													
V	2010	ALL	Powertrain	Rear Drive System																																																													
V	2010	ALL	Powertrain	Transmission Control Module																																																													
V	2010	ALL	Chassis	Electronic Brake Control Module			V																																																									
V	2010	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
V	2010	ALL	Body	Digital Radio Receiver																																																													
V	2010	ALL	Body	Driver Door Switch																																																													
V	2010	ALL	Body	Head Up Display																																																													
V	2010	ALL	Body	Heated Seat Module																																																													
V	2010	ALL	Body	HVAC Control Module Auto																																																													
V	2010	ALL	Body	HVAC Control Module Manual																																																													
V	2010	ALL	Body	Instrument Panel Cluster																																																													
V	2010	ALL	Body	Lift Gate Module																									V	V			V	V																																
V	2010	ALL	Body	Park Assist Module																																																													
V	2010	ALL	Body	Passenger Door Switch																																																													
V	2010	ALL	Body	Passenger Presence System																						V																																								
V	2010	ALL	Body	Radio																																																													
V	2010	ALL	Body	Rear HVAC/RSA																																																													
V	2010	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
V	2010	ALL	Body	Theft Deterrent Module																																																													
V	2011	ALL	Powertrain	Engine Control Module																																																														
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																													
V	2011	ALL	Powertrain	Rear Drive System																																																													
V	2011	ALL	Powertrain	Transmission Control Module																																																													
V	2011	ALL	Chassis	Electronic Brake Control Module			V																																																									
V	2011	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																							
V	2011	ALL	Body	Digital Radio Receiver																																																													
V	2011	ALL	Body	Driver Door Switch																																																													
V	2011	ALL	Body	Head Up Display																																																													
V	2011	ALL	Body	Heated Seat Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
V	2011	ALL	Body	HVAC Control Module Auto																																																												
V	2011	ALL	Body	HVAC Control Module Manual																																																												
V	2011	ALL	Body	Instrument Panel Cluster																																																												
V	2011	ALL	Body	Lift Gate Module																									V	V			V	V																															
V	2011	ALL	Body	Park Assist Module																																																											
V	2011	ALL	Body	Passenger Door Switch																																																											
V	2011	ALL	Body	Passenger Presence System																						V																																						
V	2011	ALL	Body	Radio																																																											
V	2011	ALL	Body	Rear HVAC/RSA																																																												
V	2011	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
V	2011	ALL	Body	Theft Deterrent Module																																																											
V	2012	ALL	Powertrain	Engine Control Module										V																																																	
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2012	ALL	Powertrain	Rear Drive System																																																												
V	2012	ALL	Powertrain	Transmission Control Module																																																												
V	2012	ALL	Chassis	Electronic Brake Control Module			V																																																									
V	2012	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																						
V	2012	ALL	Body	Digital Radio Receiver																																																												
V	2012	ALL	Body	Driver Door Switch																																																												
V	2012	ALL	Body	Head Up Display																																																												
V	2012	ALL	Body	Heated Seat Module																																																												
V	2012	ALL	Body	HVAC Control Module Auto																																																												
V	2012	ALL	Body	HVAC Control Module Manual																																																												
V	2012	ALL	Body	Instrument Panel Cluster																																																												
V	2012	ALL	Body	Lift Gate Module																									V	V			V	V																															
V	2012	ALL	Body	Park Assist Module																																																											
V	2012	ALL	Body	Passenger Door Switch																																																												
V	2012	ALL	Body	Passenger Presence System																						V																																						
V	2012	ALL	Body	Radio																																																											
V	2012	ALL	Body	Rear HVAC/RSA																																																												
V	2012	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
V	2012	ALL	Body	Theft Deterrent Module																																																												
V	2013	ALL	Powertrain	Engine Control Module										V																																																		
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2013	ALL	Powertrain	Rear Drive System																																																												
V	2013	ALL	Powertrain	Transmission Control Module																																																												
V	2013	ALL	Chassis	Electronic Brake Control Module			V																																																									
V	2013	ALL	Body	Body Control Module															V	V	V	V	V	V	V																																						
V	2013	ALL	Body	Digital Radio Receiver																																																												
V	2013	ALL	Body	Driver Door Switch																																																												
V	2013	ALL	Body	Head Up Display																																																												
V	2013	ALL	Body	Heated Seat Module																																																												
V	2013	ALL	Body	HVAC Control Module Auto																																																												
V	2013	ALL	Body	HVAC Control Module Manual																																																												
V	2013	ALL	Body	Instrument Panel Cluster																																																												
V	2013	ALL	Body	Left Side Object Detection Module																																																												
V	2013	ALL	Body	Lift Gate Module																									V	V			V	V																															
V	2013	ALL	Body	Park Assist Module																																																											
V	2013	ALL	Body	Passenger Door Switch																																																											
V	2013	ALL	Body	Passenger Presence System																						V																																						
V	2013	ALL	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
V	2013	ALL	Body	Rear HVAC/RSA																																																											
V	2013	ALL	Body	Right Side Object Detection Module																																																												
V	2013	ALL	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
V	2013	ALL	Body	Theft Deterrent Module																																																											
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2014	Acadia	Powertrain	Chassis Control Module																																																												
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
V	2014	Acadia	Chassis	Electronic Brake Control Module																																																												
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																				V	V	V	V	V	V	V	V	V	V													
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																				V	V	V	V	V	V	V	V	V	V													
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2014	Acadia	Body	Passenger Presence Module																																																V										
V	2014	Acadia	Body	Instrument Cluster																																																												
V	2014	Acadia	Body	Head-Up Display Module																																																												
V	2014	Acadia	Body	Radio																																																												
V	2014	Acadia	Body	Rear Audio Control Module																																																												
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																												
V	2014	Acadia	Body	Personal Audio Link Control Module																																																												
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																V										
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																V										
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																											
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																												
V	2014	Acadia	Body	Liftgate Control Module																																																				V	V	V	V				
V	2014	Acadia	Body	Seat Memory Control Module																																																							V	V
V	2014	Acadia	Body	Front Seat Heating Control Module																																																												
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																												
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																												
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																												
V	2014	Acadia	Body	Parking Assist Control Module																																																												
V	2014	Acadia	Body	Frontview Camera Module																																																												
V	2014	Acadia	Body	Theft Deterrent Module																																																												
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
V	2015	Acadia	Chassis	Electronic Brake Control Module																																																												
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																				V	V	V	V	V	V	V	V	V	V													
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																				V	V	V	V	V	V	V	V	V	V													
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2015	Acadia	Body	Passenger Presence Module																																																V										
V	2015	Acadia	Body	Instrument Cluster																																																												
V	2015	Acadia	Body	Head-Up Display Module																																																												
V	2015	Acadia	Body	Radio																																																											
V	2015	Acadia	Body	Rear Audio Control Module																																																												
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																												
V	2015	Acadia	Body	Personal Audio Link Control Module																																																												
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																V										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																	V								
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																									
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																									
V	2015	Acadia	Body	Liftgate Control Module																																																			V	V	V	V			
V	2015	Acadia	Body	Seat Memory Control Module																																																							V	V
V	2015	Acadia	Body	Front Seat Heating Control Module																																																								
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																								
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																								
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																								
V	2015	Acadia	Body	Parking Assist Control Module																																																								
V	2015	Acadia	Body	Frontview Camera Module																																																								
V	2015	Acadia	Body	Theft Deterrent Module																																																								
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																								
V	2016	Acadia	Chassis	Electronic Brake Control Module																																																								
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																				V	V	V	V	V	V	V	V	V	V										
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																				V	V	V	V	V	V	V	V	V	V										
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
V	2016	Acadia	Body	Passenger Presence Module																																																	V								
V	2016	Acadia	Body	Instrument Cluster																																																								
V	2016	Acadia	Body	Head-Up Display Module																																																								
V	2016	Acadia	Body	Radio																																																								
V	2016	Acadia	Body	Rear Audio Control Module																																																								
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																								
V	2016	Acadia	Body	Personal Audio Link Control Module																																																								
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																								
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																	V								
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																	V								
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																								
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																								
V	2016	Acadia	Body	Liftgate Control Module																																																			V	V	V	V			
V	2016	Acadia	Body	Seat Memory Control Module																																																							V	V
V	2016	Acadia	Body	Front Seat Heating Control Module																																																								
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																								
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																								
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																								
V	2016	Acadia	Body	Parking Assist Control Module																																																								
V	2016	Acadia	Body	Frontview Camera Module																																																								
V	2016	Acadia	Body	Theft Deterrent Module																																																								
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module										V																																																			
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																	
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module										V																																																	
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES			V																																																									
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
1	2011	Sierra	Chassis	Electronic Suspension Control																																																												
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																												
1	2011	Sierra	Body	Amplifier (Bose)																																																												
1	2011	Sierra	Body	Body Control Module															V	V	V	V	V	V	V																																							
1	2011	Sierra	Body	Body Control Module (aux.)																																																												
1	2011	Sierra	Body	Digital Radio Receiver																																																												
1	2011	Sierra	Body	Driver Door Switch																																																												
1	2011	Sierra	Body	HVAC Control Module Auto																																																												
1	2011	Sierra	Body	HVAC Control Module Manual																																																												
1	2011	Sierra	Body	Instrument Panel Cluster																																																												
1	2011	Sierra	Body	Memory Seat Module																																																												
1	2011	Sierra	Body	Park Assist Module																																																												
1	2011	Sierra	Body	Passenger Door Switch																																																												
1	2011	Sierra	Body	Passenger Presence System																																																												
1	2011	Sierra	Body	Radio																																																											
1	2011	Sierra	Body	Rear Heated Seat Module																																																												
1	2011	Sierra	Body	Rear HVAC/RSA																																																												
1	2011	Sierra	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
1	2011	Sierra	Body	Theft Deterrent Module																																																												
1	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																												
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																												
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																												
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																												
1	2011	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																							

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																												
1	2011	Sierra Hybrid	Body	Driver Door Switch																																																												
1	2011	Sierra Hybrid	Body	Heated Seat Module																																																												
1	2011	Sierra Hybrid	Body	HVAC Control Module																																																												
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
1	2011	Sierra Hybrid	Body	Park Assist Module																																																												
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																																												
1	2011	Sierra Hybrid	Body	Passenger Presence System																																																												
1	2011	Sierra Hybrid	Body	Radio																																																												
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																												
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
1	2011	Yukon	Chassis	Electronic Brake Control Module			V																																																									
1	2011	Yukon	Chassis	Electronic Suspension Control																																																												
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																												
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
1	2011	Yukon	Body	Amplifier (Bose)																																																												
1	2011	Yukon	Body	Assist Step Controller																																																												
1	2011	Yukon	Body	Body Control Module															V	V	V	V	V	V	V																																						
1	2011	Yukon	Body	Body Control Module (aux.)																																																												
1	2011	Yukon	Body	Digital Radio Receiver																																																												
1	2011	Yukon	Body	Driver Door Switch																																																												
1	2011	Yukon	Body	HVAC Control Module Auto																																																												
1	2011	Yukon	Body	HVAC Control Module Manual																																																												
1	2011	Yukon	Body	Instrument Panel Cluster																																																												
1	2011	Yukon	Body	Left Side Object Detection Module						V																																																					
1	2011	Yukon	Body	Lift Gate Module																									V	V			V	V																														
1	2011	Yukon	Body	Memory Seat Module																																																											
1	2011	Yukon	Body	Park Assist Module																																																											
1	2011	Yukon	Body	Passenger Door Switch																																																											
1	2011	Yukon	Body	Passenger Presence System																																																											
1	2011	Yukon	Body	Radio																																																										
1	2011	Yukon	Body	Rear Heated Seat Module																																																											
1	2011	Yukon	Body	Rear HVAC/RSA																																																											
1	2011	Yukon	Body	Right Side Object Detection Module						V																																																				
1	2011	Yukon	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
1	2011	Yukon	Body	Theft Deterrent Module																																																											
1	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																											
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																												
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																												
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																												
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																												
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																												
1	2011	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																							
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																												
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																												
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																												
1	2011	Yukon Hybrid	Body	HVAC Control Module																																																												
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module						V																																																						
1	2011	Yukon Hybrid	Body	Lift Gate Module																									V	V			V	V																														
1	2011	Yukon Hybrid	Body	Park Assist Module																																																												
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																												
1	2011	Yukon Hybrid	Body	Passenger Presence System																																																												
1	2011	Yukon Hybrid	Body	Radio																																																												
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module						V																																																						
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																V	V	V	V																									
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																												
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW			V																																																									
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																												
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																												
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
1	2011	Yukon XL	Body	Amplifier (Bose)																																																												
1	2011	Yukon XL	Body	Assist Step Controller																																																												
1	2011	Yukon XL	Body	Body Control Module															V	V	V	V	V	V	V																																							
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																												
1	2011	Yukon XL	Body	Digital Radio Receiver																																																												
1	2011	Yukon XL	Body	Driver Door Switch																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2011	Yukon XL	Body	HVAC Control Module Auto																																																											
1	2011	Yukon XL	Body	HVAC Control Module Manual																																																											
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																											
1	2011	Yukon XL	Body	Left Side Object Detection Module						V																																																				
1	2011	Yukon XL	Body	Lift Gate Module																								V	V			V	V																														
1	2011	Yukon XL	Body	Memory Seat Module																																																										
1	2011	Yukon XL	Body	Park Assist Module																																																										
1	2011	Yukon XL	Body	Passenger Door Switch																																																										
1	2011	Yukon XL	Body	Passenger Presence System																																																										
1	2011	Yukon XL	Body	Radio																																																										
1	2011	Yukon XL	Body	Rear Heated Seat Module																																																										
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																										
1	2011	Yukon XL	Body	Right Side Object Detection Module						V																																																				
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
1	2011	Yukon XL	Body	Theft Deterrent Module																																																										
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module										V																																																
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																															
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module										V																																															
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES			V																																																							
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
1	2012	Sierra	Chassis	Electronic Suspension Control																																																										
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																										
1	2012	Sierra	Body	Amplifier (Bose)																																																										
1	2012	Sierra	Body	Body Control Module															V	V	V	V	V	V	V																																				
1	2012	Sierra	Body	Body Control Module (aux.)																																																										
1	2012	Sierra	Body	Digital Radio Receiver																																																										
1	2012	Sierra	Body	Driver Door Switch																																																										
1	2012	Sierra	Body	HVAC Control Module Auto																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2012	Sierra	Body	HVAC Control Module Manual																																																												
1	2012	Sierra	Body	Instrument Panel Cluster																																																												
1	2012	Sierra	Body	Memory Seat Module																																																												
1	2012	Sierra	Body	Park Assist Module																																																												
1	2012	Sierra	Body	Passenger Door Switch																																																												
1	2012	Sierra	Body	Passenger Presence System																																																												
1	2012	Sierra	Body	Radio																																																												
1	2012	Sierra	Body	Navigation Radio																																																												
1	2012	Sierra	Body	Rear Heated Seat Module																																																												
1	2012	Sierra	Body	Rear HVAC/RSA																																																												
1	2012	Sierra	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
1	2012	Sierra	Body	Theft Deterrent Module																																																												
1	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																												
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																												
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																												
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																												
1	2012	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																						
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																												
1	2012	Sierra Hybrid	Body	Driver Door Switch																																																												
1	2012	Sierra Hybrid	Body	Heated Seat Module																																																												
1	2012	Sierra Hybrid	Body	HVAC Control Module																																																												
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
1	2012	Sierra Hybrid	Body	Park Assist Module																																																												
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																																												
1	2012	Sierra Hybrid	Body	Passenger Presence System																																																												
1	2012	Sierra Hybrid	Body	Radio																																																												
1	2012	Sierra Hybrid	Body	Navigation Radio																																																												
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																										
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																												
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
1	2012	Yukon	Chassis	Electronic Brake Control Module			V																																																									
1	2012	Yukon	Chassis	Electronic Suspension Control																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																											
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon	Body	Amplifier (Bose)																																																											
1	2012	Yukon	Body	Assist Step Controller																																																											
1	2012	Yukon	Body	Body Control Module															V	V	V	V	V	V	V																																						
1	2012	Yukon	Body	Body Control Module (aux.)																																																											
1	2012	Yukon	Body	Digital Radio Receiver																																																											
1	2012	Yukon	Body	Driver Door Switch																																																											
1	2012	Yukon	Body	HVAC Control Module Auto																																																											
1	2012	Yukon	Body	HVAC Control Module Manual																																																											
1	2012	Yukon	Body	Instrument Panel Cluster																																																											
1	2012	Yukon	Body	Left Side Object Detection Module						V																																																					
1	2012	Yukon	Body	Lift Gate Module																									V	V			V	V																														
1	2012	Yukon	Body	Memory Seat Module																																																											
1	2012	Yukon	Body	Park Assist Module																																																											
1	2012	Yukon	Body	Passenger Door Switch																																																											
1	2012	Yukon	Body	Passenger Presence System																																																											
1	2012	Yukon	Body	Radio																																																											
1	2012	Yukon	Body	Navigation Radio																																																											
1	2012	Yukon	Body	Rear Heated Seat Module																																																											
1	2012	Yukon	Body	Rear HVAC/RSA																																																											
1	2012	Yukon	Body	Right Side Object Detection Module						V																																																					
1	2012	Yukon	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
1	2012	Yukon	Body	Theft Deterrent Module																																																											
1	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																											
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																											
1	2012	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																					
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																											
1	2012	Yukon Hybrid	Body	Driver Door Switch																																																											
1	2012	Yukon Hybrid	Body	Heated Seat Module																																																											
1	2012	Yukon Hybrid	Body	HVAC Control Module																																																											
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module						V																																																					
1	2012	Yukon Hybrid	Body	Lift Gate Module																									V	V			V	V																														
1	2012	Yukon Hybrid	Body	Park Assist Module																																																											
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																																											
1	2012	Yukon Hybrid	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2012	Yukon Hybrid	Body	Radio																																																										
1	2012	Yukon Hybrid	Body	Navigation Radio																																																										
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module						V																																																				
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																										
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW			V																																																							
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																										
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Yukon XL	Body	Amplifier (Bose)																																																										
1	2012	Yukon XL	Body	Assist Step Controller																																																										
1	2012	Yukon XL	Body	Body Control Module														V	V	V	V	V	V	V																																						
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2012	Yukon XL	Body	Digital Radio Receiver																																																										
1	2012	Yukon XL	Body	Driver Door Switch																																																										
1	2012	Yukon XL	Body	HVAC Control Module Auto																																																										
1	2012	Yukon XL	Body	HVAC Control Module Manual																																																										
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																										
1	2012	Yukon XL	Body	Left Side Object Detection Module						V																																																				
1	2012	Yukon XL	Body	Lift Gate Module																									V	V			V	V																												
1	2012	Yukon XL	Body	Memory Seat Module																																																										
1	2012	Yukon XL	Body	Park Assist Module																																																										
1	2012	Yukon XL	Body	Passenger Door Switch																																																										
1	2012	Yukon XL	Body	Passenger Presence System																																																										
1	2012	Yukon XL	Body	Radio																																																										
1	2012	Yukon XL	Body	Navigation Radio																																																										
1	2012	Yukon XL	Body	Rear Heated Seat Module																																																										
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																										
1	2012	Yukon XL	Body	Right Side Object Detection Module						V																																																				
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
1	2012	Yukon XL	Body	Theft Deterrent Module																																																										
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																													
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																													
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																													
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module										V																																																		
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																													
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																													
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																													
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module										V																																																			
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																													
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																													
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES			V																																																										
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																													
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																													
1	2013	Sierra	Chassis	Electronic Suspension Control																																																													
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																													
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																													
1	2013	Sierra	Body	Amplifier (Bose)																																																													
1	2013	Sierra	Body	Body Control Module															V	V	V	V	V	V	V																																							
1	2013	Sierra	Body	Body Control Module (aux.)																																																													
1	2013	Sierra	Body	Digital Radio Receiver																																																													
1	2013	Sierra	Body	Driver Door Switch																																																													
1	2013	Sierra	Body	HVAC Control Module Auto																																																													
1	2013	Sierra	Body	HVAC Control Module Manual																																																													
1	2013	Sierra	Body	Instrument Panel Cluster																																																													
1	2013	Sierra	Body	Memory Seat Module																																																													
1	2013	Sierra	Body	Park Assist Module																																																													
1	2013	Sierra	Body	Passenger Door Switch																																																													
1	2013	Sierra	Body	Passenger Presence System																																																													
1	2013	Sierra	Body	Radio																																																													
1	2013	Sierra	Body	Navigation Radio																																																													
1	2013	Sierra	Body	Rear Heated Seat Module																																																													
1	2013	Sierra	Body	Rear HVAC/RSA																																																													
1	2013	Sierra	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
1	2013	Sierra	Body	Theft Deterrent Module																																																													
1	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																													
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																													
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																													
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																													
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																													
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																													
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																													
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																													
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																													
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																													
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																													
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																													
1	2013	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																							
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																													
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																													
1	2013	Sierra Hybrid	Body	Driver Door Switch																																																													
1	2013	Sierra Hybrid	Body	Heated Seat Module																																																													
1	2013	Sierra Hybrid	Body	HVAC Control Module																																																													
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																													
1	2013	Sierra Hybrid	Body	Park Assist Module																																																													
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																																													
1	2013	Sierra Hybrid	Body	Passenger Presence System																																																													
1	2013	Sierra Hybrid	Body	Radio																																																													
1	2013	Sierra Hybrid	Body	Navigation Radio																																																													
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																													
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																													
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																													
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																											
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																													
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																													
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																													
1	2013	Yukon	Chassis	Electronic Brake Control Module			V																																																										
1	2013	Yukon	Chassis	Electronic Suspension Control																																																													
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																													
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																													
1	2013	Yukon	Body	Amplifier (Bose)																																																													
1	2013	Yukon	Body	Assist Step Controller																																																													
1	2013	Yukon	Body	Body Control Module															V	V	V	V	V	V	V																																							
1	2013	Yukon	Body	Body Control Module (aux.)																																																													
1	2013	Yukon	Body	Digital Radio Receiver																																																													
1	2013	Yukon	Body	Driver Door Switch																																																													
1	2013	Yukon	Body	HVAC Control Module Auto																																																													
1	2013	Yukon	Body	HVAC Control Module Manual																																																													
1	2013	Yukon	Body	Instrument Panel Cluster																																																													
1	2013	Yukon	Body	Left Side Object Detection Module						V																																																						
1	2013	Yukon	Body	Lift Gate Module																									V	V			V	V																														
1	2013	Yukon	Body	Memory Seat Module																																																													
1	2013	Yukon	Body	Park Assist Module																																																													
1	2013	Yukon	Body	Passenger Door Switch																																																													
1	2013	Yukon	Body	Passenger Presence System																																																													
1	2013	Yukon	Body	Radio																																																													
1	2013	Yukon	Body	Navigation Radio																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2013	Yukon	Body	Rear Heated Seat Module																																																											
1	2013	Yukon	Body	Rear HVAC/RSA																																																											
1	2013	Yukon	Body	Right Side Object Detection Module						V																																																				
1	2013	Yukon	Body	Supplemental Inflatable Restraint																															V	V	V	V																							
1	2013	Yukon	Body	Theft Deterrent Module																																																										
1	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																										
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2013	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																				
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2013	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2013	Yukon Hybrid	Body	Heated Seat Module																																																										
1	2013	Yukon Hybrid	Body	HVAC Control Module																																																										
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module						V																																																			
1	2013	Yukon Hybrid	Body	Lift Gate Module																								V	V			V	V																													
1	2013	Yukon Hybrid	Body	Park Assist Module																																																										
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2013	Yukon Hybrid	Body	Passenger Presence System																																																										
1	2013	Yukon Hybrid	Body	Radio																																																										
1	2013	Yukon Hybrid	Body	Navigation Radio																																																										
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module						V																																																			
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																							
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																										
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																													
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW			V																																																										
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																													
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																												
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon XL	Body	Amplifier (Bose)																																																												
1	2013	Yukon XL	Body	Assist Step Controller																																																												
1	2013	Yukon XL	Body	Body Control Module															V	V	V	V	V	V	V																																							
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																												
1	2013	Yukon XL	Body	Digital Radio Receiver																																																												
1	2013	Yukon XL	Body	Driver Door Switch																																																												
1	2013	Yukon XL	Body	HVAC Control Module Auto																																																												
1	2013	Yukon XL	Body	HVAC Control Module Manual																																																												
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																												
1	2013	Yukon XL	Body	Left Side Object Detection Module						V																																																					
1	2013	Yukon XL	Body	Lift Gate Module																									V	V			V	V																														
1	2013	Yukon XL	Body	Memory Seat Module																																																											
1	2013	Yukon XL	Body	Park Assist Module																																																											
1	2013	Yukon XL	Body	Passenger Door Switch																																																											
1	2013	Yukon XL	Body	Passenger Presence System																																																											
1	2013	Yukon XL	Body	Radio																																																											
1	2013	Yukon XL	Body	Navigation Radio																																																											
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																											
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																											
1	2013	Yukon XL	Body	Right Side Object Detection Module						V																																																					
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
1	2013	Yukon XL	Body	Theft Deterrent Module																																																											
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																											
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2014	Sierra	Chassis	Electronic Brake Control Module																																																											
1	2014	Sierra	Chassis	Parking Brake Control Module																																																											
1	2014	Sierra	Chassis	Power Steering Control Module																																																											
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Sierra	Body	Body Control Module																																																											
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	Sierra	Body	Passenger Presence Module																																																											
1	2014	Sierra	Body	Instrument Cluster																																																											
1	2014	Sierra	Body	Radio Control																																																											
1	2014	Sierra	Body	HVAC Control																																																											
1	2014	Sierra	Body	Radio																																																											
1	2014	Sierra	Body	Amplifier																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2014	Sierra	Body	Media Disc Player																																																										
1	2014	Sierra	Body	Human Machine Interface Control Module																																																										
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2014	Sierra	Body	Parking Assist Control Module																																																										
1	2014	Sierra	Body	Frontview Camera Module																																																										
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																										
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Suspension Control Module																																																										
1	2014	Sierra HD	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Sierra HD	Body	Instrument Cluster																																																										
1	2014	Sierra HD	Body	Base Radio																																																										
1	2014	Sierra HD	Body	Navigation Radio																																																										
1	2014	Sierra HD	Body	Uplevel Radio																																																										
1	2014	Sierra HD	Body	Amplifier																																																										
1	2014	Sierra HD	Body	Rear Audio Control Module																																																										
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																										
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																										
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																V										
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																V										
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																V										
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																V										
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Sierra HD	Body	Seat Memory Control Module																																																								V	V	
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																										
1	2014	Sierra HD	Body	Parking Assist Control Module																																																										
1	2014	Sierra HD	Body	Theft Deterrent Module																																																										
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																										
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										

| Engine type | Year | Model | System 1 | System 2 | New Actuator Setup Procedure | VSCM Data | Signal Data | VSCM Disable Reason | VSCM Power Steering Reset | Range Measurements | Module Data | Inhibit Data | Calibrate Module | Exh. Aftertreatment Data | Parking Brake Shoe Service Reset | Parking Brake Actuator DTC Reset | Parking Brake Switch Procedure | Charging Info | RVS Disable 1 History | RVS Disable 2 History | RVS Disable 3 History | RVS Disable 4 History | RVS Disable 5 History | RVS Disable 6 History | RVS Disable 7 History | Passenger presence system learn | Signal Type | Module ID Information | Open History Data | Close History Data | Last Open Fail Data | Last Close Fail Data | Obstacle Detect Opening Data | Obstacle Detect Closing Data | LGM Open/Close Test | Deployment Loop 1-14 Resistance | Deployment Loop 15-18 Resistance | Deployment Loop Configuration | Sensor Configuration | Parking Brake Calibration | CAN Bus Communication | Remote Vehicle Start Data | Remote Vehicle Start Disable History 1 Data | Remote Vehicle Start Disable History 2 Data | Remote Vehicle Start Disable History 3 Data | Remote Vehicle Start Disable History 4 Data | Remote Vehicle Start Disable History 5 Data | Remote Vehicle Start Disable History 6 Data | Remote Vehicle Start Disable History 7 Data | Steering Wheel Control Switches | Vehicle Access | Passenger Presence Data | HVAC Door Position Data | A/C Permission Data | Last Liftgate Close Malfunction Data | Last Liftgate Open Malfunction Data | Engineering Data 1 | Engineering Data 2 | Seat Position Data | Steering Column Data |
|---|---|---

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2014	Yukon XL	Body	Uplevel Radio																																																										
1	2014	Yukon XL	Body	Amplifier																																																										
1	2014	Yukon XL	Body	Rear Audio Control Module																																																										
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																										
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																																										
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Yukon XL	Body	Liftgate Control Module																																																										
1	2014	Yukon XL	Body	Seat Memory Control Module																																																										
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																										
1	2014	Yukon XL	Body	Assist Step Control Module																																																										
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																										
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																										
1	2014	Yukon XL	Body	Parking Assist Control Module																																																										
1	2014	Yukon XL	Body	Theft Deterrent Module																																																										
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Sierra	Chassis	Power Steering Control Module																																																										
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Sierra	Chassis	Suspension Control Module																																																										
1	2015	Sierra	Body	Body Control Module																																						V																				

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2015	Sierra	Body	Passenger Presence Module																																																												
1	2015	Sierra	Body	Instrument Cluster																																																												
1	2015	Sierra	Body	Radio Controls																																																												
1	2015	Sierra	Body	HVAC Controls																																																												
1	2015	Sierra	Body	Radio																																																												
1	2015	Sierra	Body	Amplifier																																																												
1	2015	Sierra	Body	Media Disc Player																																																												
1	2015	Sierra	Body	Human Machine Interface Control Module																																																												
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																												
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																												
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
1	2015	Sierra	Body	Parking Assist Control Module																																																												
1	2015	Sierra	Body	Frontview Camera Module																																																												
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																												
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																												
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																												
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																												
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																												
1	2015	Yukon	Chassis	Electronic Brake Control Module																																																												
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																												
1	2015	Yukon	Chassis	Parking Brake Control Module																																																												
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2015	Yukon	Chassis	Power Steering Control Module																																																												
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2015	Yukon	Chassis	Suspension Control Module																																																												
1	2015	Yukon	Body	Body Control Module																																																												
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2015	Yukon	Body	Passenger Presence Module																																																												
1	2015	Yukon	Body	Instrument Cluster																																																												
1	2015	Yukon	Body	Radio Controls																																																												
1	2015	Yukon	Body	HVAC Controls																																																												
1	2015	Yukon	Body	Radio																																																											
1	2015	Yukon	Body	Amplifier																																																											
1	2015	Yukon	Body	Media Disc Player																																																												
1	2015	Yukon	Body	Human Machine Interface Control Module																																																												
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																												
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																												
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2015	Yukon	Body	HVAC Control Module																																																											
1	2015	Yukon	Body	Liftgate Control Module																																																					V	V	V	V		
1	2015	Yukon	Body	Keyless Entry Control Module																																																										
1	2015	Yukon	Body	Assist Step Control Module																																																										
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon	Body	Parking Assist Control Module																																																										
1	2015	Yukon	Body	Frontview Camera Module																																																										
1	2015	Yukon	Body	Steering Column Lock Control Module																																																										
1	2015	Yukon	Body	Battery Energy Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	Yukon XL	Chassis	Power Steering Control Module																																																										
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Yukon XL	Chassis	Suspension Control Module																																																										
1	2015	Yukon XL	Body	Body Control Module																																																										
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Yukon XL	Body	Passenger Presence Module																																																										
1	2015	Yukon XL	Body	Instrument Cluster																																																										
1	2015	Yukon XL	Body	Radio Controls																																																										
1	2015	Yukon XL	Body	HVAC Controls																																																										
1	2015	Yukon XL	Body	Radio																																																										
1	2015	Yukon XL	Body	Amplifier																																																										
1	2015	Yukon XL	Body	Media Disc Player																																																										
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Yukon XL	Body	HVAC Control Module																																																										
1	2015	Yukon XL	Body	Liftgate Control Module																																																					V	V	V	V		
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
1	2015	Yukon XL	Body	Assist Step Control Module																																																										
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon XL	Body	Parking Assist Control Module																																																										
1	2015	Yukon XL	Body	Frontview Camera Module																																																										
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																												
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																												
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																												
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																												
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																												
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																												
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																												
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2016	Sierra	Chassis	Electronic Brake Control Module																																																												
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																												
1	2016	Sierra	Chassis	Parking Brake Control Module																																																												
1	2016	Sierra	Chassis	Power Steering Control Module																																																												
1	2016	Sierra	Chassis	Power Steering Control Module																																																												
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2016	Sierra	Chassis	Suspension Control Module																																																												
1	2016	Sierra	Body	Body Control Module																																																												
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2016	Sierra	Body	Passenger Presence Module																																																												
1	2016	Sierra	Body	Instrument Cluster																																																												
1	2016	Sierra	Body	Radio Controls																																																												
1	2016	Sierra	Body	HVAC Controls																																																												
1	2016	Sierra	Body	Radio (IO3)																																																												
1	2016	Sierra	Body	Radio (IOB)																																																												
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																												
1	2016	Sierra	Body	Amplifier																																																												
1	2016	Sierra	Body	Media Disc Player																																																												
1	2016	Sierra	Body	Human Machine Interface Control Module																																																												
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																												
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																												
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																												
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																												
1	2016	Sierra	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2016	Sierra	Body	Frontview Camera Module																																																														
1	2016	Sierra	Body	Frontview Camera Module																																																													
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																													
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																													
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
1	2016	Yukon	Chassis	Electronic Brake Control Module																																																													
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																													
1	2016	Yukon	Chassis	Parking Brake Control Module																																																													
1	2016	Yukon	Chassis	Power Steering Control Module																																																													
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																													
1	2016	Yukon	Chassis	Suspension Control Module																																																													
1	2016	Yukon	Body	Body Control Module																																																													
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
1	2016	Yukon	Body	Passenger Presence Module																																																													
1	2016	Yukon	Body	Instrument Cluster																																																													
1	2016	Yukon	Body	Radio Controls																																																													
1	2016	Yukon	Body	HVAC Controls																																																													
1	2016	Yukon	Body	Radio																																																													
1	2016	Yukon	Body	Amplifier																																																													
1	2016	Yukon	Body	Media Disc Player																																																													
1	2016	Yukon	Body	Human Machine Interface Control Module																																																													
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																													
1	2016	Yukon	Body	HVAC Control Module																																																													
1	2016	Yukon	Body	Liftgate Control Module																																																								V	V	V	V		
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																													
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																													
1	2016	Yukon	Body	Keyless Entry Control Module																																																													
1	2016	Yukon	Body	Assist Step Control Module																																																													
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																													
1	2016	Yukon	Body	Parking Assist Control Module																																																													
1	2016	Yukon	Body	Frontview Camera Module																																																													
1	2016	Yukon	Body	Steering Column Lock Control Module																																																													
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																													
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																													
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																													
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																													
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																													
1	2016	Yukon XL	Chassis	Power Steering Control Module																																																													
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																													
1	2016	Yukon XL	Chassis	Suspension Control Module																																																													
1	2016	Yukon XL	Body	Body Control Module																																																													
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
1	2016	Yukon XL	Body	Passenger Presence Module																																																															
1	2016	Yukon XL	Body	Instrument Cluster																																																															
1	2016	Yukon XL	Body	Radio Controls																																																															
1	2016	Yukon XL	Body	HVAC Controls																																																															
1	2016	Yukon XL	Body	Radio																																																															
1	2016	Yukon XL	Body	Amplifier																																																															
1	2016	Yukon XL	Body	Media Disc Player																																																															
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																															
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																															
1	2016	Yukon XL	Body	HVAC Control Module																																																															
1	2016	Yukon XL	Body	Liftgate Control Module																																																							V	V	V	V		
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																															
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																															
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																															
1	2016	Yukon XL	Body	Assist Step Control Module																																																															
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																															
1	2016	Yukon XL	Body	Parking Assist Control Module																																																															
1	2016	Yukon XL	Body	Frontview Camera Module																																																															
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																															
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																															
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																															
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																															
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																															
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																															
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																															
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																															
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module										V																																																				
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																															
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																															
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																															
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																				
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																															
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																															
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																															
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																															
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module										V																																																				
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																															
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																															
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES			V																																																										
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																													
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													
2	2011	Sierra	Chassis	Electronic Suspension Control																																																													
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																													
2	2011	Sierra	Body	Amplifier (Bose)																																																													
2	2011	Sierra	Body	Body Control Module															V	V	V	V	V	V	V																																								
2	2011	Sierra	Body	Body Control Module (aux.)																																																													
2	2011	Sierra	Body	Digital Radio Receiver																																																													
2	2011	Sierra	Body	Driver Door Switch																																																													
2	2011	Sierra	Body	HVAC Control Module Auto																																																													
2	2011	Sierra	Body	HVAC Control Module Manual																																																													
2	2011	Sierra	Body	Instrument Panel Cluster																																																													
2	2011	Sierra	Body	Memory Seat Module																																																													
2	2011	Sierra	Body	Park Assist Module																																																													
2	2011	Sierra	Body	Passenger Door Switch																																																													
2	2011	Sierra	Body	Passenger Presence System																																																													
2	2011	Sierra	Body	Radio																																																													
2	2011	Sierra	Body	Rear Heated Seat Module																																																													
2	2011	Sierra	Body	Rear HVAC/RSA																																																													
2	2011	Sierra	Body	Supplemental Inflatable Restraint																															V	V	V	V																												
2	2011	Sierra	Body	Theft Deterrent Module																																																													
2	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																													
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																													
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																													
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																													
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																													
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																													
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																													
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																													
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																													
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																													
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																													
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																													
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																													
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																													
2	2011	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																								
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																													
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																													
2	2011	Sierra Hybrid	Body	Driver Door Switch																																																													
2	2011	Sierra Hybrid	Body	Heated Seat Module																																																													
2	2011	Sierra Hybrid	Body	HVAC Control Module																																																													
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																													
2	2011	Sierra Hybrid	Body	Park Assist Module																																																													
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																																													
2	2011	Sierra Hybrid	Body	Passenger Presence System																																																													
2	2011	Sierra Hybrid	Body	Radio																																																													
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																													
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																V	V	V	V																						
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2011	Yukon	Chassis	Electronic Brake Control Module			V																																																							
2	2011	Yukon	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																										
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon	Body	Amplifier (Bose)																																																										
2	2011	Yukon	Body	Assist Step Controller																																																										
2	2011	Yukon	Body	Body Control Module															V	V	V	V	V	V	V																																					
2	2011	Yukon	Body	Body Control Module (aux.)																																																										
2	2011	Yukon	Body	Digital Radio Receiver																																																										
2	2011	Yukon	Body	Driver Door Switch																																																										
2	2011	Yukon	Body	HVAC Control Module Auto																																																										
2	2011	Yukon	Body	HVAC Control Module Manual																																																										
2	2011	Yukon	Body	Instrument Panel Cluster																																																										
2	2011	Yukon	Body	Left Side Object Detection Module						V																																																				
2	2011	Yukon	Body	Lift Gate Module																									V	V			V	V																												
2	2011	Yukon	Body	Memory Seat Module																																																										
2	2011	Yukon	Body	Park Assist Module																																																										
2	2011	Yukon	Body	Passenger Door Switch																																																										
2	2011	Yukon	Body	Passenger Presence System																																																										
2	2011	Yukon	Body	Radio																																																										
2	2011	Yukon	Body	Rear Heated Seat Module																																																										
2	2011	Yukon	Body	Rear HVAC/RSA																																																										
2	2011	Yukon	Body	Right Side Object Detection Module						V																																																				
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																V	V	V	V																						
2	2011	Yukon	Body	Theft Deterrent Module																																																										
2	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																												
2	2011	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																							
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																												
2	2011	Yukon Hybrid	Body	Driver Door Switch																																																												
2	2011	Yukon Hybrid	Body	Heated Seat Module																																																												
2	2011	Yukon Hybrid	Body	HVAC Control Module																																																												
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module						V																																																						
2	2011	Yukon Hybrid	Body	Lift Gate Module																									V	V			V	V																														
2	2011	Yukon Hybrid	Body	Park Assist Module																																																												
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																																												
2	2011	Yukon Hybrid	Body	Passenger Presence System																																																												
2	2011	Yukon Hybrid	Body	Radio																																																												
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module						V																																																						
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																V	V	V	V																									
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																												
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																												
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																												
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																												
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																												
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW			V																																																									
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																												
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																												
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
2	2011	Yukon XL	Body	Amplifier (Bose)																																																												
2	2011	Yukon XL	Body	Assist Step Controller																																																												
2	2011	Yukon XL	Body	Body Control Module															V	V	V	V	V	V	V																																							
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																												
2	2011	Yukon XL	Body	Digital Radio Receiver																																																												
2	2011	Yukon XL	Body	Driver Door Switch																																																												
2	2011	Yukon XL	Body	HVAC Control Module Auto																																																												
2	2011	Yukon XL	Body	HVAC Control Module Manual																																																												
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																												
2	2011	Yukon XL	Body	Left Side Object Detection Module						V																																																						

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2011	Yukon XL	Body	Lift Gate Module																									V	V			V	V																												
2	2011	Yukon XL	Body	Memory Seat Module																																																										
2	2011	Yukon XL	Body	Park Assist Module																																																										
2	2011	Yukon XL	Body	Passenger Door Switch																																																										
2	2011	Yukon XL	Body	Passenger Presence System																																																										
2	2011	Yukon XL	Body	Radio																																																										
2	2011	Yukon XL	Body	Rear Heated Seat Module																																																										
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																										
2	2011	Yukon XL	Body	Right Side Object Detection Module						V																																																				
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
2	2011	Yukon XL	Body	Theft Deterrent Module																																																										
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module										V																																															
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																															
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module										V																																															
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES			V																																																							
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
2	2012	Sierra	Chassis	Electronic Suspension Control																																																										
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																										
2	2012	Sierra	Body	Amplifier (Bose)																																																										
2	2012	Sierra	Body	Body Control Module															V	V	V	V	V	V	V																																					

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2012	Sierra	Body	Body Control Module (aux.)																																																										
2	2012	Sierra	Body	Digital Radio Receiver																																																										
2	2012	Sierra	Body	Driver Door Switch																																																										
2	2012	Sierra	Body	HVAC Control Module Auto																																																										
2	2012	Sierra	Body	HVAC Control Module Manual																																																										
2	2012	Sierra	Body	Instrument Panel Cluster																																																										
2	2012	Sierra	Body	Memory Seat Module																																																										
2	2012	Sierra	Body	Park Assist Module																																																										
2	2012	Sierra	Body	Passenger Door Switch																																																										
2	2012	Sierra	Body	Passenger Presence System																																																										
2	2012	Sierra	Body	Radio																																																										
2	2012	Sierra	Body	Navigation Radio																																																										
2	2012	Sierra	Body	Rear Heated Seat Module																																																										
2	2012	Sierra	Body	Rear HVAC/RSA																																																										
2	2012	Sierra	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
2	2012	Sierra	Body	Theft Deterrent Module																																																										
2	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																					
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2012	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2012	Sierra Hybrid	Body	Park Assist Module																																																										
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2012	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2012	Sierra Hybrid	Body	Radio																																																										
2	2012	Sierra Hybrid	Body	Navigation Radio																																																										
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																												
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																												
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
2	2012	Yukon	Chassis	Electronic Brake Control Module			V																																																									
2	2012	Yukon	Chassis	Electronic Suspension Control																																																												
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																												
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
2	2012	Yukon	Body	Amplifier (Bose)																																																												
2	2012	Yukon	Body	Assist Step Controller																																																												
2	2012	Yukon	Body	Body Control Module															V	V	V	V	V	V	V																																							
2	2012	Yukon	Body	Body Control Module (aux.)																																																												
2	2012	Yukon	Body	Digital Radio Receiver																																																												
2	2012	Yukon	Body	Driver Door Switch																																																												
2	2012	Yukon	Body	HVAC Control Module Auto																																																												
2	2012	Yukon	Body	HVAC Control Module Manual																																																												
2	2012	Yukon	Body	Instrument Panel Cluster																																																												
2	2012	Yukon	Body	Left Side Object Detection Module						V																																																					
2	2012	Yukon	Body	Lift Gate Module																									V	V			V	V																														
2	2012	Yukon	Body	Memory Seat Module																																																											
2	2012	Yukon	Body	Park Assist Module																																																											
2	2012	Yukon	Body	Passenger Door Switch																																																											
2	2012	Yukon	Body	Passenger Presence System																																																											
2	2012	Yukon	Body	Radio																																																											
2	2012	Yukon	Body	Navigation Radio																																																											
2	2012	Yukon	Body	Rear Heated Seat Module																																																											
2	2012	Yukon	Body	Rear HVAC/RSA																																																											
2	2012	Yukon	Body	Right Side Object Detection Module						V																																																					
2	2012	Yukon	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
2	2012	Yukon	Body	Theft Deterrent Module																																																											
2	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																											
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																											
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																											
2	2012	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																					
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																											
2	2012	Yukon Hybrid	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2012	Yukon Hybrid	Body	Heated Seat Module																																																												
2	2012	Yukon Hybrid	Body	HVAC Control Module																																																												
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module						V																																																					
2	2012	Yukon Hybrid	Body	Lift Gate Module																								V	V			V	V																															
2	2012	Yukon Hybrid	Body	Park Assist Module																																																											
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																																											
2	2012	Yukon Hybrid	Body	Passenger Presence System																																																											
2	2012	Yukon Hybrid	Body	Radio																																																											
2	2012	Yukon Hybrid	Body	Navigation Radio																																																											
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module						V																																																					
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW			V																																																								
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																											
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																											
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
2	2012	Yukon XL	Body	Amplifier (Bose)																																																											
2	2012	Yukon XL	Body	Assist Step Controller																																																											
2	2012	Yukon XL	Body	Body Control Module															V	V	V	V	V	V	V																																					
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																											
2	2012	Yukon XL	Body	Digital Radio Receiver																																																											
2	2012	Yukon XL	Body	Driver Door Switch																																																											
2	2012	Yukon XL	Body	HVAC Control Module Auto																																																											
2	2012	Yukon XL	Body	HVAC Control Module Manual																																																											
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																											
2	2012	Yukon XL	Body	Left Side Object Detection Module						V																																																					
2	2012	Yukon XL	Body	Lift Gate Module																								V	V			V	V																															
2	2012	Yukon XL	Body	Memory Seat Module																																																											
2	2012	Yukon XL	Body	Park Assist Module																																																											
2	2012	Yukon XL	Body	Passenger Door Switch																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2012	Yukon XL	Body	Passenger Presence System																																																											
2	2012	Yukon XL	Body	Radio																																																											
2	2012	Yukon XL	Body	Navigation Radio																																																											
2	2012	Yukon XL	Body	Rear Heated Seat Module																																																											
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																											
2	2012	Yukon XL	Body	Right Side Object Detection Module						V																																																				
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
2	2012	Yukon XL	Body	Theft Deterrent Module																																																											
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module										V																																																
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																											
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module										V																																																
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																											
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES			V																																																								
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																											
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																											
2	2013	Sierra	Chassis	Electronic Suspension Control																																																											
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
2	2013	Sierra	Body	Amplifier (Bose)																																																											
2	2013	Sierra	Body	Body Control Module															V	V	V	V	V	V	V																																					
2	2013	Sierra	Body	Body Control Module (aux.)																																																											
2	2013	Sierra	Body	Digital Radio Receiver																																																											
2	2013	Sierra	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2013	Sierra	Body	HVAC Control Module Auto																																																												
2	2013	Sierra	Body	HVAC Control Module Manual																																																												
2	2013	Sierra	Body	Instrument Panel Cluster																																																												
2	2013	Sierra	Body	Memory Seat Module																																																												
2	2013	Sierra	Body	Park Assist Module																																																												
2	2013	Sierra	Body	Passenger Door Switch																																																												
2	2013	Sierra	Body	Passenger Presence System																																																												
2	2013	Sierra	Body	Radio																																																												
2	2013	Sierra	Body	Navigation Radio																																																												
2	2013	Sierra	Body	Rear Heated Seat Module																																																												
2	2013	Sierra	Body	Rear HVAC/RSA																																																												
2	2013	Sierra	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
2	2013	Sierra	Body	Theft Deterrent Module																																																												
2	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																												
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																												
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																												
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																												
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																												
2	2013	Sierra Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																						
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																												
2	2013	Sierra Hybrid	Body	Driver Door Switch																																																												
2	2013	Sierra Hybrid	Body	Heated Seat Module																																																												
2	2013	Sierra Hybrid	Body	HVAC Control Module																																																												
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
2	2013	Sierra Hybrid	Body	Park Assist Module																																																												
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																																												
2	2013	Sierra Hybrid	Body	Passenger Presence System																																																												
2	2013	Sierra Hybrid	Body	Radio																																																												
2	2013	Sierra Hybrid	Body	Navigation Radio																																																												
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																									
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																												
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																												
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2013	Yukon	Chassis	Electronic Brake Control Module			V																																																							
2	2013	Yukon	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Body	Amplifier (Bose)																																																										
2	2013	Yukon	Body	Assist Step Controller																																																										
2	2013	Yukon	Body	Body Control Module															V	V	V	V	V	V	V																																					
2	2013	Yukon	Body	Body Control Module (aux.)																																																										
2	2013	Yukon	Body	Digital Radio Receiver																																																										
2	2013	Yukon	Body	Driver Door Switch																																																										
2	2013	Yukon	Body	HVAC Control Module Auto																																																										
2	2013	Yukon	Body	HVAC Control Module Manual																																																										
2	2013	Yukon	Body	Instrument Panel Cluster																																																										
2	2013	Yukon	Body	Left Side Object Detection Module						V																																																				
2	2013	Yukon	Body	Lift Gate Module																									V	V			V	V																												
2	2013	Yukon	Body	Memory Seat Module																																																										
2	2013	Yukon	Body	Park Assist Module																																																										
2	2013	Yukon	Body	Passenger Door Switch																																																										
2	2013	Yukon	Body	Passenger Presence System																																																										
2	2013	Yukon	Body	Radio																																																										
2	2013	Yukon	Body	Navigation Radio																																																										
2	2013	Yukon	Body	Rear Heated Seat Module																																																										
2	2013	Yukon	Body	Rear HVAC/RSA																																																										
2	2013	Yukon	Body	Right Side Object Detection Module						V																																																				
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																V	V	V	V																							
2	2013	Yukon	Body	Theft Deterrent Module																																																										
2	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2013	Yukon Hybrid	Body	Body Control Module															V	V	V	V	V	V	V																																					
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Yukon Hybrid	Body	Driver Door Switch																																																										
2	2013	Yukon Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2013	Yukon Hybrid	Body	HVAC Control Module																																																												
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module						V																																																					
2	2013	Yukon Hybrid	Body	Lift Gate Module																								V	V			V	V																														
2	2013	Yukon Hybrid	Body	Park Assist Module																																																											
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																																											
2	2013	Yukon Hybrid	Body	Passenger Presence System																																																											
2	2013	Yukon Hybrid	Body	Radio																																																											
2	2013	Yukon Hybrid	Body	Navigation Radio																																																											
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module						V																																																					
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																											
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																											
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																											
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																											
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																											
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW			V																																																								
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																											
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
2	2013	Yukon XL	Body	Amplifier (Bose)																																																											
2	2013	Yukon XL	Body	Assist Step Controller																																																											
2	2013	Yukon XL	Body	Body Control Module															V	V	V	V	V	V	V																																					
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																											
2	2013	Yukon XL	Body	Digital Radio Receiver																																																											
2	2013	Yukon XL	Body	Driver Door Switch																																																											
2	2013	Yukon XL	Body	HVAC Control Module Auto																																																											
2	2013	Yukon XL	Body	HVAC Control Module Manual																																																											
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																											
2	2013	Yukon XL	Body	Left Side Object Detection Module						V																																																					
2	2013	Yukon XL	Body	Lift Gate Module																								V	V			V	V																														
2	2013	Yukon XL	Body	Memory Seat Module																																																											
2	2013	Yukon XL	Body	Park Assist Module																																																											
2	2013	Yukon XL	Body	Passenger Door Switch																																																											
2	2013	Yukon XL	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2013	Yukon XL	Body	Radio																																																										
2	2013	Yukon XL	Body	Navigation Radio																																																										
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																										
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																										
2	2013	Yukon XL	Body	Right Side Object Detection Module						V																																																				
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																															V	V	V	V																								
2	2013	Yukon XL	Body	Theft Deterrent Module																																																										
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2014	Sierra	Chassis	Electronic Brake Control Module																																																										
2	2014	Sierra	Chassis	Parking Brake Control Module																																																										
2	2014	Sierra	Chassis	Power Steering Control Module																																																										
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2014	Sierra	Body	Body Control Module																																																										
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Sierra	Body	Passenger Presence Module																																																										
2	2014	Sierra	Body	Instrument Cluster																																																										
2	2014	Sierra	Body	Radio Control																																																										
2	2014	Sierra	Body	HVAC Control																																																										
2	2014	Sierra	Body	Radio																																																										
2	2014	Sierra	Body	Amplifier																																																										
2	2014	Sierra	Body	Media Disc Player																																																										
2	2014	Sierra	Body	Human Machine Interface Control Module																																																										
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2014	Sierra	Body	Parking Assist Control Module																																																										
2	2014	Sierra	Body	Frontview Camera Module																																																										
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																										
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																										
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																										
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2014	Sierra HD	Chassis	Suspension Control Module																																																											
2	2014	Sierra HD	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V												
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Sierra HD	Body	Instrument Cluster																																																										
2	2014	Sierra HD	Body	Base Radio																																																										
2	2014	Sierra HD	Body	Navigation Radio																																																										
2	2014	Sierra HD	Body	Uplevel Radio																																																										
2	2014	Sierra HD	Body	Amplifier																																																										
2	2014	Sierra HD	Body	Rear Audio Control Module																																																										
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																										
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																										
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																	V								
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																	V								
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																	V								
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																	V								
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																										
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Sierra HD	Body	Seat Memory Control Module																																																									V	V
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																										
2	2014	Sierra HD	Body	Parking Assist Control Module																																																										
2	2014	Sierra HD	Body	Theft Deterrent Module																																																										
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																										
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2014	Yukon	Chassis	Parking Brake Control Module																																																										
2	2014	Yukon	Chassis	Suspension Control Module																																																										
2	2014	Yukon	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V												
2	2014	Yukon	Body	Auxiliary Body Control Module																																																										
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Yukon	Body	Passenger Presence Module																																																	V								
2	2014	Yukon	Body	Instrument Cluster																																																										
2	2014	Yukon	Body	Base Radio																																																										
2	2014	Yukon	Body	Navigation Radio																																																										
2	2014	Yukon	Body	Uplevel Radio																																																										
2	2014	Yukon	Body	Amplifier																																																										
2	2014	Yukon	Body	Rear Audio Control Module																																																										
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																										
2	2014	Yukon	Body	Personal Audio Link Control Module																																																										
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																	V								
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																	V								
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																											
2	2014	Yukon	Body	Liftgate Control Module																																																				V	V	V	V		
2	2014	Yukon	Body	Seat Memory Control Module																																																							V	V
2	2014	Yukon	Body	Rear Seat Heating Control Module																																																								
2	2014	Yukon	Body	Assist Step Control Module																																																								
2	2014	Yukon	Body	Right Side Object Detection Control Module																																																								
2	2014	Yukon	Body	Left Side Object Detection Control Module																																																								
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																								
2	2014	Yukon	Body	Parking Assist Control Module																																																								
2	2014	Yukon	Body	Theft Deterrent Module																																																								
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																								
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																								
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																								
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																								
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																								
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																								
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																								
2	2014	Yukon XL	Chassis	Suspension Control Module																																																								
2	2014	Yukon XL	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V										
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																								
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
2	2014	Yukon XL	Body	Passenger Presence Module																																																								
2	2014	Yukon XL	Body	Instrument Cluster																																																								
2	2014	Yukon XL	Body	Base Radio																																																								
2	2014	Yukon XL	Body	Navigation Radio																																																								
2	2014	Yukon XL	Body	Uplevel Radio																																																								
2	2014	Yukon XL	Body	Amplifier																																																								
2	2014	Yukon XL	Body	Rear Audio Control Module																																																								
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																								
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																								
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																								
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																								
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																	V								
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																	V								
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																								
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																								
2	2014	Yukon XL	Body	Liftgate Control Module																																																				V	V	V	V		
2	2014	Yukon XL	Body	Seat Memory Control Module																																																								V	V
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																								
2	2014	Yukon XL	Body	Assist Step Control Module																																																								
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																								
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																								
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																								
2	2014	Yukon XL	Body	Parking Assist Control Module																																																								
2	2014	Yukon XL	Body	Theft Deterrent Module																																																								
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Sierra	Chassis	Electronic Brake Control Module																																																										
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Sierra	Chassis	Power Steering Control Module																																																										
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Sierra	Chassis	Suspension Control Module																																																										
2	2015	Sierra	Body	Body Control Module																																						V																				
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Sierra	Body	Passenger Presence Module																																																										
2	2015	Sierra	Body	Instrument Cluster																																																										
2	2015	Sierra	Body	Radio Controls																																																										
2	2015	Sierra	Body	HVAC Controls																																																										
2	2015	Sierra	Body	Radio																																																										
2	2015	Sierra	Body	Amplifier																																																										
2	2015	Sierra	Body	Media Disc Player																																																										
2	2015	Sierra	Body	Human Machine Interface Control Module																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2015	Sierra	Body	Parking Assist Control Module																																																										
2	2015	Sierra	Body	Frontview Camera Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																											
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																											
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																											
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																											
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																											
2	2015	Yukon	Chassis	Electronic Brake Control Module																																																											
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																											
2	2015	Yukon	Chassis	Parking Brake Control Module																																																											
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																											
2	2015	Yukon	Chassis	Power Steering Control Module																																																											
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2015	Yukon	Chassis	Suspension Control Module																																																											
2	2015	Yukon	Body	Body Control Module																																																											
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2015	Yukon	Body	Passenger Presence Module																																																											
2	2015	Yukon	Body	Instrument Cluster																																																											
2	2015	Yukon	Body	Radio Controls																																																											
2	2015	Yukon	Body	HVAC Controls																																																											
2	2015	Yukon	Body	Radio																																																											
2	2015	Yukon	Body	Amplifier																																																											
2	2015	Yukon	Body	Media Disc Player																																																											
2	2015	Yukon	Body	Human Machine Interface Control Module																																																											
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																											
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																											
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2015	Yukon	Body	HVAC Control Module																																																											
2	2015	Yukon	Body	Liftgate Control Module																																																					V	V	V	V			
2	2015	Yukon	Body	Keyless Entry Control Module																																																											
2	2015	Yukon	Body	Assist Step Control Module																																																											
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																											
2	2015	Yukon	Body	Parking Assist Control Module																																																											
2	2015	Yukon	Body	Frontview Camera Module																																																											
2	2015	Yukon	Body	Steering Column Lock Control Module																																																											
2	2015	Yukon	Body	Battery Energy Control Module																																																											
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																											
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																											
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																											
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																											
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																											
2	2015	Yukon XL	Chassis	Power Steering Control Module																																																											
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2015	Yukon XL	Chassis	Suspension Control Module																																																											
2	2015	Yukon XL	Body	Body Control Module																																																											
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2015	Yukon XL	Body	Passenger Presence Module																																																											
2	2015	Yukon XL	Body	Instrument Cluster																																																											
2	2015	Yukon XL	Body	Radio Controls																																																											
2	2015	Yukon XL	Body	HVAC Controls																																																											
2	2015	Yukon XL	Body	Radio																																																											
2	2015	Yukon XL	Body	Amplifier																																																											
2	2015	Yukon XL	Body	Media Disc Player																																																											
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																											
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																											
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																											
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2015	Yukon XL	Body	HVAC Control Module																																																											
2	2015	Yukon XL	Body	Liftgate Control Module																																																						V	V	V	V			
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																											
2	2015	Yukon XL	Body	Assist Step Control Module																																																											
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																											
2	2015	Yukon XL	Body	Parking Assist Control Module																																																											
2	2015	Yukon XL	Body	Frontview Camera Module																																																											
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																											
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																											
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																											
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																											
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																											
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																											
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2016	Sierra	Chassis	Electronic Brake Control Module																																																												
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																												
2	2016	Sierra	Chassis	Parking Brake Control Module																																																												
2	2016	Sierra	Chassis	Power Steering Control Module																																																												
2	2016	Sierra	Chassis	Power Steering Control Module																																																												
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2016	Sierra	Chassis	Suspension Control Module																																																												
2	2016	Sierra	Body	Body Control Module																																																												
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2016	Sierra	Body	Passenger Presence Module																																																												
2	2016	Sierra	Body	Instrument Cluster																																																												
2	2016	Sierra	Body	Radio Controls																																																												
2	2016	Sierra	Body	HVAC Controls																																																												
2	2016	Sierra	Body	Radio (IO3)																																																												
2	2016	Sierra	Body	Radio (IOB)																																																												
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																												
2	2016	Sierra	Body	Amplifier																																																												
2	2016	Sierra	Body	Media Disc Player																																																												
2	2016	Sierra	Body	Human Machine Interface Control Module																																																												
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																												
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																												
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																												
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																												
2	2016	Sierra	Body	Parking Assist Control Module																																																												
2	2016	Sierra	Body	Frontview Camera Module																																																												
2	2016	Sierra	Body	Frontview Camera Module																																																												
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2016	Yukon	Chassis	Electronic Brake Control Module																																																												
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																												
2	2016	Yukon	Chassis	Parking Brake Control Module																																																												
2	2016	Yukon	Chassis	Power Steering Control Module																																																												
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2016	Yukon	Chassis	Suspension Control Module																																																												
2	2016	Yukon	Body	Body Control Module																																																												
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2016	Yukon	Body	Passenger Presence Module																																																												
2	2016	Yukon	Body	Instrument Cluster																																																												
2	2016	Yukon	Body	Radio Controls																																																												
2	2016	Yukon	Body	HVAC Controls																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
2	2016	Yukon	Body	Radio																																																												
2	2016	Yukon	Body	Amplifier																																																												
2	2016	Yukon	Body	Media Disc Player																																																												
2	2016	Yukon	Body	Human Machine Interface Control Module																																																												
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																												
2	2016	Yukon	Body	HVAC Control Module																																																												
2	2016	Yukon	Body	Liftgate Control Module																																																							V	V	V	V		
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																												
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																												
2	2016	Yukon	Body	Keyless Entry Control Module																																																												
2	2016	Yukon	Body	Assist Step Control Module																																																												
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																												
2	2016	Yukon	Body	Parking Assist Control Module																																																												
2	2016	Yukon	Body	Frontview Camera Module																																																												
2	2016	Yukon	Body	Steering Column Lock Control Module																																																												
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																												
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																												
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																												
2	2016	Yukon XL	Chassis	Power Steering Control Module																																																												
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2016	Yukon XL	Chassis	Suspension Control Module																																																												
2	2016	Yukon XL	Body	Body Control Module																																																												
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2016	Yukon XL	Body	Passenger Presence Module																																																												
2	2016	Yukon XL	Body	Instrument Cluster																																																												
2	2016	Yukon XL	Body	Radio Controls																																																												
2	2016	Yukon XL	Body	HVAC Controls																																																												
2	2016	Yukon XL	Body	Radio																																																												
2	2016	Yukon XL	Body	Amplifier																																																												
2	2016	Yukon XL	Body	Media Disc Player																																																												
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																												
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																												
2	2016	Yukon XL	Body	HVAC Control Module																																																												
2	2016	Yukon XL	Body	Liftgate Control Module																																																							V	V	V	V		
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																												
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																												
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																												
2	2016	Yukon XL	Body	Assist Step Control Module																																																												
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																												
2	2016	Yukon XL	Body	Parking Assist Control Module																																																												
2	2016	Yukon XL	Body	Frontview Camera Module																																																												
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																												
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																		
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																				
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module										V																																																				
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																															
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																															
5	2011	ALL	Chassis	Electronic Brake Control Module																																																															
5	2011	ALL	Body	Body Control Module																																																															
5	2011	ALL	Body	Digital Radio Receiver																																																															
5	2011	ALL	Body	Generator Battery Control Module																																																															
5	2011	ALL	Body	Instrument Panel Cluster																																																															
5	2011	ALL	Body	Passenger Presence System																																																															
5	2011	ALL	Body	Personal Audio Link Module																																																															
5	2011	ALL	Body	Base Radio																																																															
5	2011	ALL	Body	Uplevel Radio																																																															
5	2011	ALL	Body	Supplemental Inflatable Restraint																																																															
5	2011	ALL	Body	Theft Deterrent Module																																																															
5	2011	ALL	Body	Vehicle Comm. Interface Module																																																															
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																					
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																															
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																					
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																															
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module										V																																																					
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																															
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																															
5	2012	ALL	Chassis	Electronic Brake Control Module																																																															
5	2012	ALL	Body	Body Control Module																																																															
5	2012	ALL	Body	Digital Radio Receiver																																																															
5	2012	ALL	Body	Generator Battery Control Module																																																															
5	2012	ALL	Body	Instrument Panel Cluster																																																															
5	2012	ALL	Body	Passenger Presence System																																																															
5	2012	ALL	Body	Personal Audio Link Module																																																															
5	2012	ALL	Body	Base Radio																																																															
5	2012	ALL	Body	Uplevel Radio																																																															
5	2012	ALL	Body	Supplemental Inflatable Restraint																																																															
5	2012	ALL	Body	Theft Deterrent Module																																																															
5	2012	ALL	Body	Vehicle Comm. Interface Module																																																															
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																															
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																															
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																															
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																															
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																															
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															
5	2015	Canyon	Powertrain	Chassis Control Module																																																															
5	2015	Canyon	Powertrain	Transfer Case Control Module																																																															
5	2015	Canyon	Chassis	Electronic Brake Control Module																																																															
5	2015	Canyon	Chassis	Power Steering Control Module																																																															
5	2015	Canyon	Body	Body Control Module																																																															

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
5	2015	Canyon	Body	Passenger Presence Module																																																													
5	2015	Canyon	Body	Radio																																																												
5	2015	Canyon	Body	Amplifier																																																												
5	2015	Canyon	Body	Human Machine Interface Control Module																																																												
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																																												
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																				V							
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																												
5	2015	Canyon	Body	Parking Assist Control Module																																																												
5	2015	Canyon	Body	Frontview Camera Module																																																												
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																												
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
5	2016	Canyon	Powertrain	Transfer Case Control Module																																																												
5	2016	Canyon	Chassis	Electronic Brake Control Module																																																												
5	2016	Canyon	Chassis	Power Steering Control Module																																																												
5	2016	Canyon	Body	Body Control Module																																																												
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
5	2016	Canyon	Body	Passenger Presence Module																																																												
5	2016	Canyon	Body	Trailer Interface Control Module																																																												
5	2016	Canyon	Body	Radio																																																												
5	2016	Canyon	Body	Amplifier																																																												
5	2016	Canyon	Body	Human Machine Interface Control Module																																																												
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																																												
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																				V							
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																												
5	2016	Canyon	Body	Frontview Camera Module																																																												
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																	
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																	
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module										V																																																	
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																												
6	2011	ALL	Chassis	Electronic Brake Control Module																																																												
6	2011	ALL	Body	Body Control Module																																																												
6	2011	ALL	Body	Digital Radio Receiver																																																												
6	2011	ALL	Body	Generator Battery Control Module																																																												
6	2011	ALL	Body	Instrument Panel Cluster																																																												
6	2011	ALL	Body	Passenger Presence System																																																												
6	2011	ALL	Body	Personal Audio Link Module																																																												
6	2011	ALL	Body	Base Radio																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
6	2011	ALL	Body	Uplevel Radio																																																										
6	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
6	2011	ALL	Body	Theft Deterrent Module																																																										
6	2011	ALL	Body	Vehicle Comm. Interface Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module										V																																																
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module										V																																																
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module										V																																																
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
6	2012	ALL	Chassis	Electronic Brake Control Module																																																										
6	2012	ALL	Body	Body Control Module																																																										
6	2012	ALL	Body	Digital Radio Receiver																																																										
6	2012	ALL	Body	Generator Battery Control Module																																																										
6	2012	ALL	Body	Instrument Panel Cluster																																																										
6	2012	ALL	Body	Passenger Presence System																																																										
6	2012	ALL	Body	Personal Audio Link Module																																																										
6	2012	ALL	Body	Base Radio																																																										
6	2012	ALL	Body	Uplevel Radio																																																										
6	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
6	2012	ALL	Body	Theft Deterrent Module																																																										
6	2012	ALL	Body	Vehicle Comm. Interface Module																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
6	2015	Canyon	Powertrain	Chassis Control Module																																																										
6	2015	Canyon	Powertrain	Transfer Case Control Module																																																										
6	2015	Canyon	Chassis	Electronic Brake Control Module																																																										
6	2015	Canyon	Chassis	Power Steering Control Module																																																										
6	2015	Canyon	Body	Body Control Module																																																										
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
6	2015	Canyon	Body	Passenger Presence Module																																																										
6	2015	Canyon	Body	Radio																																																										
6	2015	Canyon	Body	Amplifier																																																										
6	2015	Canyon	Body	Human Machine Interface Control Module																																																										
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																																										
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
6	2015	Canyon	Body	Parking Assist Control Module																																																										
6	2015	Canyon	Body	Frontview Camera Module																																																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																													
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																													
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
6	2016	Canyon	Powertrain	Transfer Case Control Module																																																													
6	2016	Canyon	Chassis	Electronic Brake Control Module																																																												
6	2016	Canyon	Chassis	Power Steering Control Module																																																												
6	2016	Canyon	Body	Body Control Module																																																												
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
6	2016	Canyon	Body	Passenger Presence Module																																																												
6	2016	Canyon	Body	Trailer Interface Control Module																																																												
6	2016	Canyon	Body	Radio																																																											
6	2016	Canyon	Body	Amplifier																																																											
6	2016	Canyon	Body	Human Machine Interface Control Module																																																											
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																																											
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																											
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																											
6	2016	Canyon	Body	Frontview Camera Module																																																											
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																	
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																											
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																	
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
7	2011	Express/Savana	Body	Body Control Module																																																											
7	2011	Express/Savana	Body	Digital Radio Receiver																																																											
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																											
7	2011	Express/Savana	Body	Passenger Presence System																																																											
7	2011	Express/Savana	Body	Radio																																																											
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
7	2011	Express/Savana	Body	Rollover Sensor																																																											
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
7	2011	Express/Savana	Body	Theft Deterrent Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																	
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																		
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2011	Express Access/Savana Pro	Body	Body Control Module																																																												
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																												
7	2011	Express Access/Savana Pro	Body	Radio																																																												
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																												
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																		
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2012	Express/Savana	Body	Body Control Module																																																												
7	2012	Express/Savana	Body	Digital Radio Receiver																																																												
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																												
7	2012	Express/Savana	Body	Passenger Presence System																																																												
7	2012	Express/Savana	Body	Radio																																																												
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
7	2012	Express/Savana	Body	Rollover Sensor																																																												
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
7	2012	Express/Savana	Body	Theft Deterrent Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																															
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																															
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																										
7	2012	Express Access/Savana Pro	Body	Radio																																																										
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2013	Express/Savana	Body	Body Control Module																																																										
7	2013	Express/Savana	Body	Digital Radio Receiver																																																										
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
7	2013	Express/Savana	Body	Passenger Presence System																																																										
7	2013	Express/Savana	Body	Radio																																																										
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
7	2013	Express/Savana	Body	Rollover Sensor																																																										
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
7	2013	Express/Savana	Body	Theft Deterrent Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module										V																																																
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2013	Express Access/Savana Pro	Body	Body Control Module																																																										
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
7	2013	Express Access/Savana Pro	Body	Radio																																																										
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2014	Savana	Chassis	Electronic Brake Control Module																																																										
7	2014	Savana	Body	Body Control Module																																			V	V	V	V	V	V	V	V	V	V	V													
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2014	Savana	Body	Passenger Presence Module																																																	V									
7	2014	Savana	Body	Rollover Sensor Module																																																										
7	2014	Savana	Body	Instrument Cluster																																																										
7	2014	Savana	Body	Chime Alarm Control Module																																																										
7	2014	Savana	Body	Base Radio																																																										
7	2014	Savana	Body	Navigation Radio																																																										
7	2014	Savana	Body	Uplevel Radio																																																										
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
7	2014	Savana	Body	Auxiliary Heater Control Module																																																											
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																											
7	2014	Savana	Body	Parking Assist Control Module																																																											
7	2014	Savana	Body	Theft Deterrent Module																																																											
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
7	2015	Savana	Chassis	Electronic Brake Control Module																																																											
7	2015	Savana	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
7	2015	Savana	Body	Rollover Sensor Module																																																											
7	2015	Savana	Body	Instrument Cluster																																																											
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																											
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											
7	2015	Savana	Body	Auxiliary Heater Control Module																																																											
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																											
7	2015	Savana	Body	Parking Assist Control Module																																																											
7	2015	Savana	Body	Theft Deterrent Module																																																											
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
7	2016	Savana	Chassis	Electronic Brake Control Module																																																											
7	2016	Savana	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
7	2016	Savana	Body	Instrument Cluster																																																											
7	2016	Savana	Body	Chime Alarm Control Module																																																											
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																											
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																											
7	2016	Savana	Body	Auxiliary Heater Control Module																																																											
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																											
7	2016	Savana	Body	Parking Assist Control Module																																																											
7	2016	Savana	Body	Theft Deterrent Module																																																											
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2011	Express/Savana	Body	Body Control Module																																																												
8	2011	Express/Savana	Body	Digital Radio Receiver																																																												
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																												
8	2011	Express/Savana	Body	Passenger Presence System																																																												
8	2011	Express/Savana	Body	Radio																																																												
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
8	2011	Express/Savana	Body	Rollover Sensor																																																												
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
8	2011	Express/Savana	Body	Theft Deterrent Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2011	Express Access/Savana Pro	Body	Body Control Module																																																												
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																												
8	2011	Express Access/Savana Pro	Body	Radio																																																												
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																												
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																		
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2012	Express/Savana	Body	Body Control Module																																																												
8	2012	Express/Savana	Body	Digital Radio Receiver																																																												
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																												
8	2012	Express/Savana	Body	Passenger Presence System																																																												
8	2012	Express/Savana	Body	Radio																																																												
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
8	2012	Express/Savana	Body	Rollover Sensor																																																										
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
8	2012	Express/Savana	Body	Theft Deterrent Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																										
8	2012	Express Access/Savana Pro	Body	Radio																																																										
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2013	Express/Savana	Body	Body Control Module																																																										
8	2013	Express/Savana	Body	Digital Radio Receiver																																																										
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
8	2013	Express/Savana	Body	Navigation Radio																																																										
8	2013	Express/Savana	Body	Park Assist Module																																																										
8	2013	Express/Savana	Body	Passenger Presence System																																																										
8	2013	Express/Savana	Body	Radio																																																										
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
8	2013	Express/Savana	Body	Rollover Sensor																																																										
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
8	2013	Express/Savana	Body	Theft Deterrent Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module										V																																																	
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
8	2013	Express Access/Savana Pro	Body	Body Control Module																																																											
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																											
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																											
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																																											
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																											
8	2013	Express Access/Savana Pro	Body	Radio																																																											
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																											
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																											
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																											
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																											
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																											
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																											
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																											
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																											
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
8	2014	Savana	Chassis	Electronic Brake Control Module																																																											
8	2014	Savana	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
8	2014	Savana	Body	Passenger Presence Module																																																											
8	2014	Savana	Body	Rollover Sensor Module																																																											
8	2014	Savana	Body	Instrument Cluster																																																											
8	2014	Savana	Body	Chime Alarm Control Module																																																											
8	2014	Savana	Body	Base Radio																																																										
8	2014	Savana	Body	Navigation Radio																																																										
8	2014	Savana	Body	Uplevel Radio																																																										
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
8	2014	Savana	Body	Auxiliary Heater Control Module																																																										
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
8	2014	Savana	Body	Parking Assist Control Module																																																										
8	2014	Savana	Body	Theft Deterrent Module																																																										
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																													
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																													
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																													
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																													
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
8	2015	Savana	Chassis	Electronic Brake Control Module																																																													
8	2015	Savana	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V														
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
8	2015	Savana	Body	Rollover Sensor Module																																																													
8	2015	Savana	Body	Instrument Cluster																																																													
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																												
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																												
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																												
8	2015	Savana	Body	Auxiliary Heater Control Module																																																												
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																												
8	2015	Savana	Body	Parking Assist Control Module																																																											
8	2015	Savana	Body	Theft Deterrent Module																																																												
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
8	2016	Savana	Chassis	Electronic Brake Control Module																																																												
8	2016	Savana	Body	Body Control Module																																				V	V	V	V	V	V	V	V	V	V													
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
8	2016	Savana	Body	Instrument Cluster																																																												
8	2016	Savana	Body	Chime Alarm Control Module																																																												
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																												
8	2016	Savana	Body	Telematics Communication Interface Control Module																																																												
8	2016	Savana	Body	Auxiliary Heater Control Module																																																												
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																												
8	2016	Savana	Body	Parking Assist Control Module																																																											
8	2016	Savana	Body	Theft Deterrent Module																																																												
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																												
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																												
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																												
ALL	2004	ALL	Chassis	ABS																																																												
ALL	2004	ALL	Chassis	Air Suspension																																																												
ALL	2004	ALL	Body	Amplifier (Bose)																																																												
ALL	2004	ALL	Body	Body Control Module																																																												
ALL	2004	ALL	Body	Digital Radio Receiver																																																												
ALL	2004	ALL	Body	Driver Door Module																																																												
ALL	2004	ALL	Body	Driver Seat Module																																																												
ALL	2004	ALL	Body	Heating and Air Conditioning																																																												
ALL	2004	ALL	Body	Instrument Panel Cluster																																																												
ALL	2004	ALL	Body	OnStar																																																												
ALL	2004	ALL	Body	Passenger Door Module																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
ALL	2004	ALL	Body	Uplevel Radio																																																											
ALL	2004	ALL	Body	Navigation Radio																																																											
ALL	2004	ALL	Body	Rear Seat Audio																																																											
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																											
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																											
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																											
ALL	2005	ALL	Chassis	ABS																																																											
ALL	2005	ALL	Chassis	Air Suspension																																																											
ALL	2005	ALL	Body	Body Control Module																																																											
ALL	2005	ALL	Body	Digital Radio Receiver																																																											
ALL	2005	ALL	Body	Driver Door Module (SUV)																																																											
ALL	2005	ALL	Body	Driver Door Module (SUT)																																																											
ALL	2005	ALL	Body	Driver Seat Module																																																											
ALL	2005	ALL	Body	Heating and Air Conditioning																																																											
ALL	2005	ALL	Body	Instrument Panel Cluster																																																											
ALL	2005	ALL	Body	Passenger Door Module																																																											
ALL	2005	ALL	Body	Uplevel Radio																																																											
ALL	2005	ALL	Body	Navigation Radio																																																											
ALL	2005	ALL	Body	Rear Seat Audio																																																											
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																											
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																											
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																											
ALL	2006	H2	Chassis	ABS																																																											
ALL	2006	H2	Chassis	Air Suspension																																																											
ALL	2006	H2	Body	Body Control Module																																																											
ALL	2006	H2	Body	Digital Radio Receiver																																																											
ALL	2006	H2	Body	Driver Door Module (SUV)																																																											
ALL	2006	H2	Body	Driver Door Module (SUT)																																																											
ALL	2006	H2	Body	Driver Seat Module																																																											
ALL	2006	H2	Body	Heating and Air Conditioning																																																											
ALL	2006	H2	Body	Instrument Panel Cluster																																																											
ALL	2006	H2	Body	Passenger Door Module																																																											
ALL	2006	H2	Body	Uplevel Radio																																																											
ALL	2006	H2	Body	Navigation Radio																																																											
ALL	2006	H2	Body	Rear Seat Audio																																																											
ALL	2006	H2	Body	Supplemental Inflatable Restraint																																																											
ALL	2006	H3	Powertrain	Engine Control Module																																																											
ALL	2006	H3	Powertrain	Transmission Control Module																																																											
ALL	2006	H3	Powertrain	Transfer Case Control Module																																																											
ALL	2006	H3	Chassis	Antilock Brake System																																																											
ALL	2006	H3	Body	Body Control Module																																																											
ALL	2006	H3	Body	Digital Radio Receiver																																																											
ALL	2006	H3	Body	Instrument Panel Cluster																																																											
ALL	2006	H3	Body	Uplevel Radio																																																											
ALL	2006	H3	Body	Navigation Radio																																																											
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																																											
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																											
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																											
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																											

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
ALL	2007	H2	Chassis	ABS																																																										
ALL	2007	H2	Chassis	Air Suspension																																																										
ALL	2007	H2	Body	Amplifier (Bose)																																																										
ALL	2007	H2	Body	Body Control Module																																																										
ALL	2007	H2	Body	Digital Radio Receiver																																																										
ALL	2007	H2	Body	Driver Door Module (SUV)																																																										
ALL	2007	H2	Body	Driver Door Module (SUT)																																																										
ALL	2007	H2	Body	Driver Seat Module																																																										
ALL	2007	H2	Body	HVAC Control Module																																																										
ALL	2007	H2	Body	Instrument Panel Cluster																																																										
ALL	2007	H2	Body	Passenger Door Module																																																										
ALL	2007	H2	Body	Uplevel Radio																																																										
ALL	2007	H2	Body	Navigation Radio																																																										
ALL	2007	H2	Body	Rear Seat Audio																																																										
ALL	2007	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																										
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																										
ALL	2007	H3	Chassis	EBCM																																																										
ALL	2007	H3	Body	Body Control Module (5GT)																																																										
ALL	2007	H3	Body	Body Control Module (ADM)																																																										
ALL	2007	H3	Body	Digital Radio Receiver																																																										
ALL	2007	H3	Body	Generator Battery Control Module																																																										
ALL	2007	H3	Body	Instrument Panel Cluster																																																										
ALL	2007	H3	Body	Personal Audio Link Module																																																										
ALL	2007	H3	Body	Uplevel Radio																																																										
ALL	2007	H3	Body	Navigation Radio																																																										
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2008	H2	Chassis	Air SCM																																																										
ALL	2008	H2	Chassis	EBCM																																																										
ALL	2008	H2	Body	Amplifier (Bose)																																																										
ALL	2008	H2	Body	Body Control Module																																																										
ALL	2008	H2	Body	Digital Radio Receiver																																																										
ALL	2008	H2	Body	Driver Door Switch																																																										
ALL	2008	H2	Body	HVAC Control Module																																																										
ALL	2008	H2	Body	Instrument Panel Cluster																																																										
ALL	2008	H2	Body	Memory Seat Module																																																										
ALL	2008	H2	Body	Passenger Door Switch																																																										
ALL	2008	H2	Body	Radio																																																										
ALL	2008	H2	Body	Rear Heated Seat Module																																																										
ALL	2008	H2	Body	Rear HVAC/RSA																																																										
ALL	2008	H2	Body	Rollover Sensor																																																										
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	H2	Body	Theft Deterrent Module																																																										
ALL	2008	H2	Body	Vehicle Comm. Interface Module																								V																																		

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)																																																													
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																													
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																													
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																													
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module																																																													
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																													
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																																													
ALL	2008	H3	Chassis	EBCM																																																														
ALL	2008	H3	Body	Body Control Module (5GT)																																																													
ALL	2008	H3	Body	Body Control Module (ADM)																																																													
ALL	2008	H3	Body	Digital Radio Receiver																																																													
ALL	2008	H3	Body	Generator Battery Control Module																																																													
ALL	2008	H3	Body	Instrument Panel Cluster																																																													
ALL	2008	H3	Body	Personal Audio Link Module																																																													
ALL	2008	H3	Body	Uplevel Radio																																																													
ALL	2008	H3	Body	Navigation Radio																																																													
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																																													
ALL	2008	H3	Body	Theft Deterrent Module																																																													
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																																													
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module										V																																																			
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																													
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																													
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																													
ALL	2009	H2	Chassis	Air SCM																																																														
ALL	2009	H2	Chassis	EBCM																																																													
ALL	2009	H2	Body	Amplifier (Bose)																																																													
ALL	2009	H2	Body	Body Control Module															V	V	V	V	V	V	V																																							
ALL	2009	H2	Body	Digital Radio Receiver																																																													
ALL	2009	H2	Body	Driver Door Switch																																																													
ALL	2009	H2	Body	HVAC Control Module																																																													
ALL	2009	H2	Body	Instrument Panel Cluster																																																													
ALL	2009	H2	Body	Memory Seat Module																																																													
ALL	2009	H2	Body	Passenger Door Switch																																																													
ALL	2009	H2	Body	Radio																																																													
ALL	2009	H2	Body	Rear Heated Seat Module																																																													
ALL	2009	H2	Body	Rear HVAC/RSA																																																													
ALL	2009	H2	Body	Rollover Sensor																																																													
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																																													
ALL	2009	H2	Body	Theft Deterrent Module																																																													
ALL	2009	H2	Body	Vehicle Comm. Interface Module																								V																																					
ALL	2009	H2	Body	Vehicle Comm. Interface Module																								V																																					
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)										V																																																		
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																													
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																													
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																													
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																													
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																													
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)										V																																																		
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)										V																																																		
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																												
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																																												
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																																												
ALL	2009	H3	Chassis	EBCM																																																												
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																																												
ALL	2009	H3	Body	Body Control Module (ADM)																																																												
ALL	2009	H3	Body	Digital Radio Receiver																																																												
ALL	2009	H3	Body	Generator Battery Control Module																																																												
ALL	2009	H3	Body	Instrument Panel Cluster																																																												
ALL	2009	H3	Body	Personal Audio Link Module																																																												
ALL	2009	H3	Body	Uplevel Radio																																																												
ALL	2009	H3	Body	Navigation Radio																																																												
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																																												
ALL	2009	H3	Body	Theft Deterrent Module																																																												
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																																												
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																												
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																												
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																												
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																												
ALL	2010	H2	Chassis	Air SCM																																																												
ALL	2010	H2	Chassis	EBCM																																																												
ALL	2010	H2	Body	Amplifier (Bose)																																																												
ALL	2010	H2	Body	Body Control Module															V	V	V	V	V	V	V																																							
ALL	2010	H2	Body	Digital Radio Receiver																																																												
ALL	2010	H2	Body	Driver Door Switch																																																												
ALL	2010	H2	Body	HVAC Control Module																																																												
ALL	2010	H2	Body	Instrument Panel Cluster																																																												
ALL	2010	H2	Body	Memory Seat Module																																																												
ALL	2010	H2	Body	Passenger Door Switch																																																												
ALL	2010	H2	Body	Personal Audio Link Module																																																												
ALL	2010	H2	Body	Radio																																																												
ALL	2010	H2	Body	Rear Heated Seat Module																																																												
ALL	2010	H2	Body	Rear HVAC/RSA																																																												
ALL	2010	H2	Body	Rollover Sensor																																																												
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																																												
ALL	2010	H2	Body	Theft Deterrent Module																																																												
ALL	2010	H2	Body	Vehicle Comm. Interface Module																								V																																				
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module										V																																																		
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																												
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																												
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																												
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																												
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module										V																																																		
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																												
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																																												
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																																												
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																																												
ALL	2010	H3	Chassis	EBCM																																																												
ALL	2010	H3	Body	Body Control Module																																																												
ALL	2010	H3	Body	Digital Radio Receiver																																																												
ALL	2010	H3	Body	Generator Battery Control Module																																																												
ALL	2010	H3	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	New Actuator Setup Procedure	VSCM Data	Signal Data	VSCM Disable Reason	VSCM Power Steering Reset	Range Measurements	Module Data	Inhibit Data	Calibrate Module	Exh. Aftertreatment Data	Parking Brake Shoe Service Reset	Parking Brake Actuator DTC Reset	Parking Brake Switch Procedure	Charging Info	RVS Disable 1 History	RVS Disable 2 History	RVS Disable 3 History	RVS Disable 4 History	RVS Disable 5 History	RVS Disable 6 History	RVS Disable 7 History	Passenger presence system learn	Signal Type	Module ID Information	Open History Data	Close History Data	Last Open Fail Data	Last Close Fail Data	Obstacle Detect Opening Data	Obstacle Detect Closing Data	LGM Open/Close Test	Deployment Loop 1-14 Resistance	Deployment Loop 15-18 Resistance	Deployment Loop Configuration	Sensor Configuration	Parking Brake Calibration	CAN Bus Communication	Remote Vehicle Start Data	Remote Vehicle Start Disable History 1 Data	Remote Vehicle Start Disable History 2 Data	Remote Vehicle Start Disable History 3 Data	Remote Vehicle Start Disable History 4 Data	Remote Vehicle Start Disable History 5 Data	Remote Vehicle Start Disable History 6 Data	Remote Vehicle Start Disable History 7 Data	Steering Wheel Control Switches	Vehicle Access	Passenger Presence Data	HVAC Door Position Data	A/C Permission Data	Last Liftgate Close Malfunction Data	Last Liftgate Open Malfunction Data	Engineering Data 1	Engineering Data 2	Seat Position Data	Steering Column Data
ALL	2010	H3	Body	Personal Audio Link Module																																																																
ALL	2010	H3	Body	Uplevel Radio																																																																
ALL	2010	H3	Body	Navigation Radio																																																																
ALL	2010	H3	Body	Supplemental Inflatable Restraint																																																																
ALL	2010	H3	Body	Theft Deterrent Module																																																																
ALL	2010	H3	Body	Vehicle Comm. Interface Module																																																																

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM											V																																														
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																														
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																														
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																														
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																														
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																														
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module										V																																															
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module											V																																														
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600											V																																														
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600											V																																														
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																														
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module										V																																															
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																															
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed											V																																														
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2004	ALL	Body	Instrument Panel Cluster																																																										
C	2004	ALL	Body	OnStar																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Radio Base																																																										
C	2004	ALL	Body	Radio Uplevel																																																										
C	2004	ALL	Body	Radio Navigation																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																											
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																										
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2004	ALL	Body	Vehicle Theft Deterrent																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM											V																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																														
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																														
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module											V																																														
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																														
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																														
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module										V																																															
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600											V																																														
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600											V																																														
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																														
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																															
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed											V																																														
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2005	ALL	Chassis	ESC																																																									
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2005	ALL	Chassis	VSES																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2005	ALL	Body	Amplifier (Bose)																																																										
C	2005	ALL	Body	Body Control Module																																																										
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																																										
C	2005	ALL	Body	Driver Seat Module																																																										
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2005	ALL	Body	Instrument Panel Cluster																																																										
C	2005	ALL	Body	Passenger Door Module																																																										
C	2005	ALL	Body	Passenger Presence System																																																										
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio																																																										
C	2005	ALL	Body	Rear Aux. Climate Module																																																										
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2005	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM											V																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																														
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																														
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module											V																																														
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																														
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module										V																																															
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600											V																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600											V																																														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module										V																																															
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																										
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																																
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed											V																																														
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																										
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																									
C	2006	ALL	Body	Amplifier (Bose)																																																										
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																										
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Sierra	Chassis	Electronic Suspension Control																																																										
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																										
C	2007	Sierra	Body	Amplifier (Bose)																																																										
C	2007	Sierra	Body	Body Control Module																																																										
C	2007	Sierra	Body	Body Control Module (aux.)																																																										
C	2007	Sierra	Body	Digital Radio Receiver																																																										
C	2007	Sierra	Body	Driver Door Switch																																																										
C	2007	Sierra	Body	HVAC Control Module Auto																																																										
C	2007	Sierra	Body	HVAC Control Module Manual																																																										
C	2007	Sierra	Body	Instrument Panel Cluster																																																										
C	2007	Sierra	Body	Memory Seat Module																																																										
C	2007	Sierra	Body	Park Assist Module																																																										
C	2007	Sierra	Body	Passenger Door Switch																																																										
C	2007	Sierra	Body	Passenger Presence System																																																										
C	2007	Sierra	Body	Radio																																																										
C	2007	Sierra	Body	Rear Heated Seat Module																																																										
C	2007	Sierra	Body	Rear HVAC/RSA																																																										
C	2007	Sierra	Body	Rollover Sensor																																																										
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2007	Sierra	Body	Theft Deterrent Module																										V	V	V	V																													
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Yukon	Chassis	Electronic Suspension Control																																																										
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																										
C	2007	Yukon	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2007	Yukon	Body	Assist Step Controller																																																										
C	2007	Yukon	Body	Body Control Module																																																										
C	2007	Yukon	Body	Body Control Module (aux.)																																																										
C	2007	Yukon	Body	Digital Radio Receiver																																																										
C	2007	Yukon	Body	Driver Door Switch																																																										
C	2007	Yukon	Body	HVAC Control Module Auto																																																										
C	2007	Yukon	Body	HVAC Control Module Manual																																																										
C	2007	Yukon	Body	Instrument Panel Cluster																																																										
C	2007	Yukon	Body	Lift Gate Module																																																										
C	2007	Yukon	Body	Memory Seat Module																																																										
C	2007	Yukon	Body	Park Assist Module																																																										
C	2007	Yukon	Body	Passenger Door Switch																																																										
C	2007	Yukon	Body	Passenger Presence System																																																										
C	2007	Yukon	Body	Radio																																																										
C	2007	Yukon	Body	Rear Heated Seat Module																																																										
C	2007	Yukon	Body	Rear HVAC/RSA																																																										
C	2007	Yukon	Body	Rollover Sensor																																																										
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																																										
C	2007	Yukon	Body	Theft Deterrent Module																										V	V	V	V																													
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2007	Yukon XL	Body	Amplifier (Bose)																																																										
C	2007	Yukon XL	Body	Assist Step Controller																																																										
C	2007	Yukon XL	Body	Body Control Module																																																										
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2007	Yukon XL	Body	Digital Radio Receiver																																																										
C	2007	Yukon XL	Body	Driver Door Switch																																																										
C	2007	Yukon XL	Body	HVAC Control Module Auto																																																										
C	2007	Yukon XL	Body	HVAC Control Module Manual																																																										
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2007	Yukon XL	Body	Lift Gate Module																																																										
C	2007	Yukon XL	Body	Memory Seat Module																																																										
C	2007	Yukon XL	Body	Park Assist Module																																																										
C	2007	Yukon XL	Body	Passenger Door Switch																																																										
C	2007	Yukon XL	Body	Passenger Presence System																																																										
C	2007	Yukon XL	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2007	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2007	Yukon XL	Body	Rollover Sensor																																																										
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
C	2007	Yukon XL	Body	Theft Deterrent Module																									V	V	V	V																														
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2008	Sierra	Chassis	Electronic Suspension Control																																																										
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																										
C	2008	Sierra	Body	Amplifier (Bose)																																																										
C	2008	Sierra	Body	Body Control Module																																																										
C	2008	Sierra	Body	Body Control Module (aux.)																																																										
C	2008	Sierra	Body	Digital Radio Receiver																																																										
C	2008	Sierra	Body	Driver Door Switch																																																										
C	2008	Sierra	Body	HVAC Control Module Auto																																																										
C	2008	Sierra	Body	HVAC Control Module Manual																																																										
C	2008	Sierra	Body	Instrument Panel Cluster																																																										
C	2008	Sierra	Body	Memory Seat Module																																																										
C	2008	Sierra	Body	Park Assist Module																																																										
C	2008	Sierra	Body	Passenger Door Switch																																																										
C	2008	Sierra	Body	Passenger Presence System																																																										
C	2008	Sierra	Body	Radio																																																										
C	2008	Sierra	Body	Rear Heated Seat Module																																																										
C	2008	Sierra	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2008	Sierra	Body	Rollover Sensor																																																										
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2008	Sierra	Body	Theft Deterrent Module																									V	V	V	V																														
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Yukon	Chassis	Electronic Brake Control Module																																																										
C	2008	Yukon	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon	Body	Amplifier (Bose)																																																										
C	2008	Yukon	Body	Assist Step Controller																																																										
C	2008	Yukon	Body	Body Control Module																																																										
C	2008	Yukon	Body	Body Control Module (aux.)																																																										
C	2008	Yukon	Body	Digital Radio Receiver																																																										
C	2008	Yukon	Body	Driver Door Switch																																																										
C	2008	Yukon	Body	HVAC Control Module Auto																																																										
C	2008	Yukon	Body	HVAC Control Module Manual																																																										
C	2008	Yukon	Body	Instrument Panel Cluster																																																										
C	2008	Yukon	Body	Lift Gate Module																																																										
C	2008	Yukon	Body	Memory Seat Module																																																										
C	2008	Yukon	Body	Park Assist Module																																																										
C	2008	Yukon	Body	Passenger Door Switch																																																										
C	2008	Yukon	Body	Passenger Presence System																																																										
C	2008	Yukon	Body	Radio																																																										
C	2008	Yukon	Body	Rear Heated Seat Module																																																										
C	2008	Yukon	Body	Rear HVAC/RSA																																																										
C	2008	Yukon	Body	Rollover Sensor																																																										
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																																										
C	2008	Yukon	Body	Theft Deterrent Module																									V	V	V	V																														
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																V										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																										
C	2008	Yukon Hybrid	Body	Body Control Module																																																										
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																										
C	2008	Yukon Hybrid	Body	HVAC Control Module																																																										
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2008	Yukon Hybrid	Body	Lift Gate Module																																																										
C	2008	Yukon Hybrid	Body	Memory Seat Module																																																										
C	2008	Yukon Hybrid	Body	Park Assist Module																																																										
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																										
C	2008	Yukon Hybrid	Body	Passenger Presence System																																																										
C	2008	Yukon Hybrid	Body	Radio																																																										
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																										
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon XL	Body	Amplifier (Bose)																																																										
C	2008	Yukon XL	Body	Assist Step Controller																																																										
C	2008	Yukon XL	Body	Body Control Module																																																										
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2008	Yukon XL	Body	Digital Radio Receiver																																																										
C	2008	Yukon XL	Body	Driver Door Switch																																																										
C	2008	Yukon XL	Body	HVAC Control Module Auto																																																										
C	2008	Yukon XL	Body	HVAC Control Module Manual																																																										
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2008	Yukon XL	Body	Lift Gate Module																																																										
C	2008	Yukon XL	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2008	Yukon XL	Body	Park Assist Module																																																										
C	2008	Yukon XL	Body	Passenger Door Switch																																																										
C	2008	Yukon XL	Body	Passenger Presence System																																																										
C	2008	Yukon XL	Body	Radio																																																										
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2008	Yukon XL	Body	Rollover Sensor																																																										
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
C	2008	Yukon XL	Body	Theft Deterrent Module																									V	V	V	V																														
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																																
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual																																																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2009	Sierra	Chassis	Electronic Suspension Control																																																										
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																										
C	2009	Sierra	Body	Amplifier (Bose)																																																										
C	2009	Sierra	Body	Body Control Module																																																										
C	2009	Sierra	Body	Body Control Module (aux.)																																																										
C	2009	Sierra	Body	Digital Radio Receiver																																																										
C	2009	Sierra	Body	Driver Door Switch																																																										
C	2009	Sierra	Body	HVAC Control Module Auto																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2009	Sierra	Body	HVAC Control Module Manual																																																										
C	2009	Sierra	Body	Instrument Panel Cluster																																																										
C	2009	Sierra	Body	Memory Seat Module																																																										
C	2009	Sierra	Body	Park Assist Module																																																										
C	2009	Sierra	Body	Passenger Door Switch																																																										
C	2009	Sierra	Body	Passenger Presence System																																																										
C	2009	Sierra	Body	Radio																																																										
C	2009	Sierra	Body	Rear Heated Seat Module																																																										
C	2009	Sierra	Body	Rear HVAC/RSA																																																										
C	2009	Sierra	Body	Rollover Sensor																																																										
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2009	Sierra	Body	Theft Deterrent Module																									V	V	V	V																														
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																										
C	2009	Sierra Hybrid	Body	Body Control Module																																																										
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																										
C	2009	Sierra Hybrid	Body	Driver Door Switch																																																										
C	2009	Sierra Hybrid	Body	HVAC Control Module																																																										
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
C	2009	Sierra Hybrid	Body	Memory Seat Module																																																										
C	2009	Sierra Hybrid	Body	Park Assist Module																																																										
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																																										
C	2009	Sierra Hybrid	Body	Passenger Presence System																																																										
C	2009	Sierra Hybrid	Body	Radio																																																										
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																										
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																									V	V	V	V																														
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed																																																										
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed																																																										
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
C	2009	Yukon	Chassis	Electronic Brake Control Module																																																										
C	2009	Yukon	Chassis	Electronic Suspension Control																																																										
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																										
C	2009	Yukon	Body	Amplifier (Bose)																																																										
C	2009	Yukon	Body	Assist Step Controller																																																										
C	2009	Yukon	Body	Body Control Module																																																									
C	2009	Yukon	Body	Body Control Module (aux.)																																																										
C	2009	Yukon	Body	Digital Radio Receiver																																																										
C	2009	Yukon	Body	Driver Door Switch																																																										
C	2009	Yukon	Body	HVAC Control Module Auto																																																										
C	2009	Yukon	Body	HVAC Control Module Manual																																																										
C	2009	Yukon	Body	Instrument Panel Cluster																																																										
C	2009	Yukon	Body	Left Side Object Detection Module																																																										
C	2009	Yukon	Body	Lift Gate Module																																																										
C	2009	Yukon	Body	Memory Seat Module																																																										
C	2009	Yukon	Body	Park Assist Module																																																										
C	2009	Yukon	Body	Passenger Door Switch																																																										
C	2009	Yukon	Body	Passenger Presence System																																																										
C	2009	Yukon	Body	Radio																																																										
C	2009	Yukon	Body	Rear Heated Seat Module																																																										
C	2009	Yukon	Body	Rear HVAC/RSA																																																										
C	2009	Yukon	Body	Right Side Object Detection Module																																																										
C	2009	Yukon	Body	Rollover Sensor																																																										
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																																										
C	2009	Yukon	Body	Theft Deterrent Module																										V	V	V	V																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																	V								
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																										
C	2009	Yukon Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2009	Yukon Hybrid	Body	Driver Door Switch																																																										
C	2009	Yukon Hybrid	Body	Heated Seat Module																																																										
C	2009	Yukon Hybrid	Body	HVAC Control Module																																																										
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
C	2009	Yukon Hybrid	Body	Park Assist Module																																																										
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																																										
C	2009	Yukon Hybrid	Body	Passenger Presence System																																																										
C	2009	Yukon Hybrid	Body	Radio																																																										
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																										
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2009	Yukon XL	Body	Amplifier (Bose)																																																										
C	2009	Yukon XL	Body	Assist Step Controller																																																										
C	2009	Yukon XL	Body	Body Control Module																																																										
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2009	Yukon XL	Body	Digital Radio Receiver																																																										
C	2009	Yukon XL	Body	Driver Door Switch																																																										
C	2009	Yukon XL	Body	HVAC Control Module Auto																																																										
C	2009	Yukon XL	Body	HVAC Control Module Manual																																																										
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2009	Yukon XL	Body	Left Side Object Detection Module																																																										
C	2009	Yukon XL	Body	Lift Gate Module																																																										
C	2009	Yukon XL	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2009	Yukon XL	Body	Park Assist Module																																																										
C	2009	Yukon XL	Body	Passenger Door Switch																																																										
C	2009	Yukon XL	Body	Passenger Presence System																																																										
C	2009	Yukon XL	Body	Radio																																																										
C	2009	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2009	Yukon XL	Body	Right Side Object Detection Module																																																										
C	2009	Yukon XL	Body	Rollover Sensor																																																										
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
C	2009	Yukon XL	Body	Theft Deterrent Module																										V	V	V	V																													
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																																
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2010	Sierra	Chassis	Electronic Suspension Control																																																										
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																										
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra	Body	Amplifier (Bose)																																																										
C	2010	Sierra	Body	Body Control Module																																																										
C	2010	Sierra	Body	Body Control Module (aux.)																																																										
C	2010	Sierra	Body	Digital Radio Receiver																																																										
C	2010	Sierra	Body	Driver Door Switch																																																										
C	2010	Sierra	Body	HVAC Control Module Auto																																																										
C	2010	Sierra	Body	HVAC Control Module Manual																																																										
C	2010	Sierra	Body	Instrument Panel Cluster																																																										
C	2010	Sierra	Body	Memory Seat Module																																																										
C	2010	Sierra	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2010	Sierra	Body	Passenger Door Switch																																																										
C	2010	Sierra	Body	Passenger Presence System																																																										
C	2010	Sierra	Body	Radio																																																										
C	2010	Sierra	Body	Rear Heated Seat Module																																																										
C	2010	Sierra	Body	Rear HVAC/RSA																																																										
C	2010	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2010	Sierra	Body	Theft Deterrent Module																										V	V	V	V																													
C	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																										
C	2010	Sierra Hybrid	Body	Body Control Module																																																										
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																										
C	2010	Sierra Hybrid	Body	Driver Door Switch																																																										
C	2010	Sierra Hybrid	Body	Heated Seat Module																																																										
C	2010	Sierra Hybrid	Body	HVAC Control Module																																																										
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
C	2010	Sierra Hybrid	Body	Park Assist Module																																																										
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																																										
C	2010	Sierra Hybrid	Body	Passenger Presence System																																																										
C	2010	Sierra Hybrid	Body	Radio																																																										
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Yukon	Chassis	Electronic Brake Control Module																																																										
C	2010	Yukon	Chassis	Electronic Suspension Control																																																										
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon	Body	Amplifier (Bose)																																																										
C	2010	Yukon	Body	Assist Step Controller																																																										
C	2010	Yukon	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2010	Yukon	Body	Body Control Module (aux.)																																																									
C	2010	Yukon	Body	Digital Radio Receiver																																																									
C	2010	Yukon	Body	Driver Door Switch																																																									
C	2010	Yukon	Body	HVAC Control Module Auto																																																									
C	2010	Yukon	Body	HVAC Control Module Manual																																																									
C	2010	Yukon	Body	Instrument Panel Cluster																																																									
C	2010	Yukon	Body	Left Side Object Detection Module																																																									
C	2010	Yukon	Body	Lift Gate Module																																																									
C	2010	Yukon	Body	Memory Seat Module																																																									
C	2010	Yukon	Body	Park Assist Module																																																									
C	2010	Yukon	Body	Passenger Door Switch																																																									
C	2010	Yukon	Body	Passenger Presence System																																																									
C	2010	Yukon	Body	Radio																																																									
C	2010	Yukon	Body	Rear Heated Seat Module																																																									
C	2010	Yukon	Body	Rear HVAC/RSA																																																									
C	2010	Yukon	Body	Right Side Object Detection Module																																																									
C	2010	Yukon	Body	Supplemental Inflatable Restraint																																																									
C	2010	Yukon	Body	Theft Deterrent Module																										V	V	V	V																												
C	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																									
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																									
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																															V										
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																									
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																									
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																									
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																									
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																									
C	2010	Yukon Hybrid	Body	Body Control Module																																																									
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																									
C	2010	Yukon Hybrid	Body	Driver Door Switch																																																									
C	2010	Yukon Hybrid	Body	Heated Seat Module																																																									
C	2010	Yukon Hybrid	Body	HVAC Control Module																																																									
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																									
C	2010	Yukon Hybrid	Body	Lift Gate Module																																																									
C	2010	Yukon Hybrid	Body	Park Assist Module																																																									
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																																									
C	2010	Yukon Hybrid	Body	Passenger Presence System																																																									
C	2010	Yukon Hybrid	Body	Radio																																																									
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																										V	V	V	V																												
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																									
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																								
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																								
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																								
C	2010	Yukon XL	Body	Amplifier (Bose)																																																								
C	2010	Yukon XL	Body	Assist Step Controller																																																								
C	2010	Yukon XL	Body	Body Control Module																																																								
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																								
C	2010	Yukon XL	Body	Digital Radio Receiver																																																								
C	2010	Yukon XL	Body	Driver Door Switch																																																								
C	2010	Yukon XL	Body	HVAC Control Module Auto																																																								
C	2010	Yukon XL	Body	HVAC Control Module Manual																																																								
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																								
C	2010	Yukon XL	Body	Left Side Object Detection Module																																																								
C	2010	Yukon XL	Body	Lift Gate Module																																																								
C	2010	Yukon XL	Body	Memory Seat Module																																																								
C	2010	Yukon XL	Body	Park Assist Module																																																								
C	2010	Yukon XL	Body	Passenger Door Switch																																																								
C	2010	Yukon XL	Body	Passenger Presence System																																																								
C	2010	Yukon XL	Body	Radio																																																								
C	2010	Yukon XL	Body	Rear Heated Seat Module																																																								
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																								
C	2010	Yukon XL	Body	Right Side Object Detection Module																																																								
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
C	2010	Yukon XL	Body	Theft Deterrent Module																										V	V	V	V																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																								
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																								
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																								
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module											V																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																								
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																								
D	2008	ALL	Chassis	Electronic Brake Control Module																																																								
D	2008	ALL	Body	Body Control Module																																																								
D	2008	ALL	Body	Body Control Module (aux.)																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
D	2008	ALL	Body	Headlamp Control Module																																																										
D	2008	ALL	Body	HVAC Control Module Auto																																																										
D	2008	ALL	Body	Instrument Panel Cluster																																																										
D	2008	ALL	Body	Park Assist Module																																																										
D	2008	ALL	Body	Remote Control Door Lock Receiver																							V	V																																			
D	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
D	2008	ALL	Body	Theft Deterrent Module																									V	V																																
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module											V																																														
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2009	ALL	Chassis	Electronic Brake Control Module																																																										
D	2009	ALL	Body	Body Control Module																																																										
D	2009	ALL	Body	Body Control Module (aux.)																																																										
D	2009	ALL	Body	Headlamp Control Module																																																										
D	2009	ALL	Body	HVAC Control Module Auto																																																										
D	2009	ALL	Body	Instrument Panel Cluster																																																										
D	2009	ALL	Body	Park Assist Module																																																										
D	2009	ALL	Body	Remote Control Door Lock Receiver																							V	V																																			
D	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
D	2009	ALL	Body	Theft Deterrent Module																									V	V																																
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module											V																																														
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2010	ALL	Chassis	Electronic Brake Control Module																																																										
D	2010	ALL	Body	Body Control Module																																																										
D	2010	ALL	Body	Body Control Module (aux.)																																																										
D	2010	ALL	Body	Headlamp Control Module																																																										
D	2010	ALL	Body	HVAC Control Module Auto																																																										
D	2010	ALL	Body	Instrument Panel Cluster																																																										
D	2010	ALL	Body	Park Assist Module																																																										
D	2010	ALL	Body	Remote Control Door Lock Receiver																							V	V																																			
D	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																														
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																														
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																														
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																									
G	2004	Express/Savana	Body	Body Control Module																																																									
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2004	Express/Savana	Body	OnStar																																																									
G	2004	Express/Savana	Body	Base Radio																																																									
G	2004	Express/Savana	Body	Uplevel Radio																																																									
G	2004	Express/Savana	Body	Remote Function Actuation																																																									
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																															
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																															
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																															
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																															
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																																										
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control											V																																															
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control											V																																															
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module											V																																															
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																															
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																															
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																															
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																														
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2005	Express/Savana	Chassis	VSES																																																									
G	2005	Express/Savana	Body	Body Control Module																																																									
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2005	Express/Savana	Body	Base Radio																																																									
G	2005	Express/Savana	Body	Uplevel Radio																																																									
G	2005	Express/Savana	Body	Remote Function Actuation																																																									
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control											V																																														
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control											V																																														
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module											V																																														
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																														
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																														
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																														
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																														
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2005	Express Access/Savana Pro	Chassis	VSES																																																									
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2005	Express Access/Savana Pro	Body	Base Radio																																																									
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control											V																																														
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control											V																																														
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																														
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																														
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																														
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																															
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2006	Express/Savana	Chassis	VSES																																																									
G	2006	Express/Savana	Body	Body Control Module																																																									
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2006	Express/Savana	Body	Passenger Presence System																																																									
G	2006	Express/Savana	Body	Base Radio																																																									
G	2006	Express/Savana	Body	Uplevel Radio																																																									
G	2006	Express/Savana	Body	Remote Function Actuation																																																									
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control											V																																														
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control											V																																														
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																														
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																														
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																														
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																														
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																															
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2006	Express Access/Savana Pro	Chassis	VSES																																																									
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2006	Express Access/Savana Pro	Body	Base Radio																																																									
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control											V																																														
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control											V																																															
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																															
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																															
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																															
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																															
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																															
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																																
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																											
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																						V																																					
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																											
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																											
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2007	Express/Savana	Body	Body Control Module																																																											
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																											
G	2007	Express/Savana	Body	Passenger Presence System																																																											
G	2007	Express/Savana	Body	Base Radio																																																											
G	2007	Express/Savana	Body	Uplevel Radio																																																											
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																																
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control											V																																																
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control											V																																																
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																																
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																																
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																																
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control											V																																																
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control											V																																																
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																																
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																						V																																					

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2007	Express Access/Savana Pro	Body	Radio																																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																														
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2008	Express/Savana	Body	Body Control Module																																																								
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2008	Express/Savana	Body	Passenger Presence System																																																								
G	2008	Express/Savana	Body	Radio																																																								
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2008	Express/Savana	Body	Rollover Sensor																																																								
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2008	Express/Savana	Body	Theft Deterrent Module																										V	V	V	V																											
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																														
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2008	Express Access/Savana Pro	Body	Radio																																																									
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																									
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																													
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2009	Express/Savana	Body	Body Control Module																																																									
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2009	Express/Savana	Body	Passenger Presence System																																																									
G	2009	Express/Savana	Body	Radio																																																								
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2009	Express/Savana	Body	Rollover Sensor																																																									
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2009	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																													
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2009	Express Access/Savana Pro	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																													
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2010	Express/Savana	Body	Body Control Module																																																										
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2010	Express/Savana	Body	Passenger Presence System																																																										
G	2010	Express/Savana	Body	Radio																																																										
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2010	Express/Savana	Body	Rollover Sensor																																																										
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2010	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																													
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2010	Express Access/Savana Pro	Body	Radio																																																								
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																										V	V	V	V																											
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																													
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2004	Express/Savana	Chassis	VSES																																																								
H	2004	Express/Savana	Body	Body Control Module																																																								
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2004	Express/Savana	Body	OnStar																																																								
H	2004	Express/Savana	Body	Base Radio																																																								
H	2004	Express/Savana	Body	Uplevel Radio																																																								
H	2004	Express/Savana	Body	Remote Function Actuation																																																								
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																													
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2004	Express Access/Savana Pro	Chassis	VSES																																																								
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2004	Express Access/Savana Pro	Body	OnStar																																																								
H	2004	Express Access/Savana Pro	Body	Base Radio																																																								
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																													
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																													
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																								
H	2005	Express/Savana	Chassis	VSES																																																								
H	2005	Express/Savana	Body	Body Control Module																																																								
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																								
H	2005	Express/Savana	Body	Base Radio																																																								
H	2005	Express/Savana	Body	Uplevel Radio																																																								
H	2005	Express/Savana	Body	Remote Function Actuation																																																								
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																													
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																													
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
H	2005	Express Access/Savana Pro	Chassis	VSES																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2005	Express Access/Savana Pro	Body	Base Radio																																																										
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																														
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2006	Express/Savana	Chassis	VSES																																																										
H	2006	Express/Savana	Body	Body Control Module																																																										
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2006	Express/Savana	Body	Passenger Presence System																																																										
H	2006	Express/Savana	Body	Base Radio																																																										
H	2006	Express/Savana	Body	Uplevel Radio																																																										
H	2006	Express/Savana	Body	Remote Function Actuation																																																										
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																														
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																														
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2006	Express Access/Savana Pro	Chassis	VSES																																																										
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2006	Express Access/Savana Pro	Body	Base Radio																																																										
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																														
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																														
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																														
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express/Savana	Body	Body Control Module																																																										
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2007	Express/Savana	Body	Passenger Presence System																																																										
H	2007	Express/Savana	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2007	Express/Savana	Body	Uplevel Radio																																																								
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																													
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control											V																																													
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control											V																																													
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2007	Express Access/Savana Pro	Body	Base Radio																																																								
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																								
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2008	Express/Savana	Body	Body Control Module																																																								
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2008	Express/Savana	Body	Passenger Presence System																																																								
H	2008	Express/Savana	Body	Radio																																																								
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2008	Express/Savana	Body	Rollover Sensor																																																								
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2008	Express/Savana	Body	Theft Deterrent Module																										V	V	V	V																											
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																														
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module																																																										
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																																										
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																														
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																														
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2010	Express/Savana	Body	Body Control Module																																																									
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2010	Express/Savana	Body	Passenger Presence System																																																									
H	2010	Express/Savana	Body	Radio																																																									
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2010	Express/Savana	Body	Rollover Sensor																																																									
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2010	Express/Savana	Body	Theft Deterrent Module																										V	V	V	V																												
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2010	Express Access/Savana Pro	Body	Radio																																																									
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																										V	V	V	V																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM											V																																														
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																														
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																														
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																														
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																														
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600											V																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600											V																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module										V																																																
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																																
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed											V																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2004	ALL	Chassis	ESC																																																									
K	2004	ALL	Chassis	Rear Wheel Steering																																																										
K	2004	ALL	Chassis	Tire Pressure Monitor																																																										
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2004	ALL	Chassis	VSES																																																									
K	2004	ALL	Body	Amplifier (Bose)																																																										
K	2004	ALL	Body	Body Control Module																																																										
K	2004	ALL	Body	CD Changer																																																										
K	2004	ALL	Body	Chime																																																										
K	2004	ALL	Body	Driver Door Module																																																										
K	2004	ALL	Body	Driver Seat Module																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2004	ALL	Body	Instrument Panel Cluster																																																										
K	2004	ALL	Body	OnStar																																																									
K	2004	ALL	Body	Passenger Door Module																																																									
K	2004	ALL	Body	Passenger Presence System																																																									
K	2004	ALL	Body	Radio Base																																																									
K	2004	ALL	Body	Radio Uplevel																																																									
K	2004	ALL	Body	Radio Navigation																																																									
K	2004	ALL	Body	Rear Aux. Climate Module																																																										
K	2004	ALL	Body	Rear HVAC																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2004	ALL	Body	Rear Seat Audio																																																										
K	2004	ALL	Body	Rear Seat Entertainment																																																										
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2004	ALL	Body	Vehicle Theft Deterrent																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM											V																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																														
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module											V																																														
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																														
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																														
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600											V																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600											V																																														
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																														
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																															
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed											V																																														
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2005	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM											V																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM											V																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM											V																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module											V																																														
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module											V																																														

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module											V																																															
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module											V																																															
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600											V																																															
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600											V																																															
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module											V																																															
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module										V																																																
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module										V																																																
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed											V																																															
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2006	ALL	Chassis	ESC																																																									
K	2006	ALL	Chassis	Tire Pressure Monitor																																																										
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2006	ALL	Chassis	VSES																																																									
K	2006	ALL	Body	Amplifier (Bose)																																																										
K	2006	ALL	Body	Body Control Module																																																									
K	2006	ALL	Body	CD Changer																																																									
K	2006	ALL	Body	Chime																																																									
K	2006	ALL	Body	Disc Player and Video Display																																																										
K	2006	ALL	Body	Driver Door Module																																																									
K	2006	ALL	Body	Driver Seat Module																																																										
K	2006	ALL	Body	Generator Battery Control Module																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2006	ALL	Body	Instrument Panel Cluster																																																										
K	2006	ALL	Body	Passenger Door Module																																																										
K	2006	ALL	Body	Passenger Presence System																																																										
K	2006	ALL	Body	Base Radio																																																										
K	2006	ALL	Body	Uplevel Radio																																																										
K	2006	ALL	Body	Navigation Radio																																																										
K	2006	ALL	Body	Rear Aux. Climate Module																																																										
K	2006	ALL	Body	Rear HVAC																																																										
K	2006	ALL	Body	Rear Seat Audio																																																										
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2006	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Sierra	Chassis	Electronic Suspension Control																																																										
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2007	Sierra	Body	Amplifier (Bose)																																																										
K	2007	Sierra	Body	Body Control Module																																																										
K	2007	Sierra	Body	Body Control Module (aux.)																																																										
K	2007	Sierra	Body	Digital Radio Receiver																																																										
K	2007	Sierra	Body	Driver Door Switch																																																										
K	2007	Sierra	Body	HVAC Control Module Auto																																																										
K	2007	Sierra	Body	HVAC Control Module Manual																																																										
K	2007	Sierra	Body	Instrument Panel Cluster																																																										
K	2007	Sierra	Body	Memory Seat Module																																																										
K	2007	Sierra	Body	Park Assist Module																																																										
K	2007	Sierra	Body	Passenger Door Switch																																																										
K	2007	Sierra	Body	Passenger Presence System																																																										
K	2007	Sierra	Body	Radio																																																										
K	2007	Sierra	Body	Rear Heated Seat Module																																																										
K	2007	Sierra	Body	Rear HVAC/RSA																																																										
K	2007	Sierra	Body	Rollover Sensor																																																										
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2007	Sierra	Body	Theft Deterrent Module																										V	V	V	V																													
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Yukon	Chassis	Electronic Suspension Control																																																										
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																										
K	2007	Yukon	Body	Amplifier (Bose)																																																										
K	2007	Yukon	Body	Assist Step Controller																																																										
K	2007	Yukon	Body	Body Control Module																																																										
K	2007	Yukon	Body	Body Control Module (aux.)																																																										
K	2007	Yukon	Body	Digital Radio Receiver																																																										
K	2007	Yukon	Body	Driver Door Switch																																																										
K	2007	Yukon	Body	HVAC Control Module Auto																																																										
K	2007	Yukon	Body	HVAC Control Module Manual																																																										
K	2007	Yukon	Body	Instrument Panel Cluster																																																										
K	2007	Yukon	Body	Lift Gate Module																																																										
K	2007	Yukon	Body	Memory Seat Module																																																										
K	2007	Yukon	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2007	Yukon	Body	Passenger Door Switch																																																									
K	2007	Yukon	Body	Passenger Presence System																																																									
K	2007	Yukon	Body	Radio																																																									
K	2007	Yukon	Body	Rear Heated Seat Module																																																									
K	2007	Yukon	Body	Rear HVAC/RSA																																																									
K	2007	Yukon	Body	Rollover Sensor																																																									
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																																									
K	2007	Yukon	Body	Theft Deterrent Module																										V	V	V	V																												
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																									
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																									
K	2007	Yukon XL	Body	Amplifier (Bose)																																																									
K	2007	Yukon XL	Body	Assist Step Controller																																																									
K	2007	Yukon XL	Body	Body Control Module																																																									
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																									
K	2007	Yukon XL	Body	Digital Radio Receiver																																																									
K	2007	Yukon XL	Body	Driver Door Switch																																																									
K	2007	Yukon XL	Body	HVAC Control Module Auto																																																									
K	2007	Yukon XL	Body	HVAC Control Module Manual																																																									
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																									
K	2007	Yukon XL	Body	Lift Gate Module																																																									
K	2007	Yukon XL	Body	Memory Seat Module																																																									
K	2007	Yukon XL	Body	Park Assist Module																																																									
K	2007	Yukon XL	Body	Passenger Door Switch																																																									
K	2007	Yukon XL	Body	Passenger Presence System																																																									
K	2007	Yukon XL	Body	Radio																																																									
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																									
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																									
K	2007	Yukon XL	Body	Rollover Sensor																																																									
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
K	2007	Yukon XL	Body	Theft Deterrent Module																										V	V	V	V																												
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Sierra	Chassis	Electronic Suspension Control																																																										
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2008	Sierra	Body	Amplifier (Bose)																																																										
K	2008	Sierra	Body	Body Control Module																																																									
K	2008	Sierra	Body	Body Control Module (aux.)																																																										
K	2008	Sierra	Body	Digital Radio Receiver																																																										
K	2008	Sierra	Body	Driver Door Switch																																																										
K	2008	Sierra	Body	HVAC Control Module Auto																																																										
K	2008	Sierra	Body	HVAC Control Module Manual																																																										
K	2008	Sierra	Body	Instrument Panel Cluster																																																										
K	2008	Sierra	Body	Memory Seat Module																																																										
K	2008	Sierra	Body	Park Assist Module																																																										
K	2008	Sierra	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2008	Sierra	Body	Passenger Presence System																																																										
K	2008	Sierra	Body	Radio																																																										
K	2008	Sierra	Body	Rear Heated Seat Module																																																										
K	2008	Sierra	Body	Rear HVAC/RSA																																																										
K	2008	Sierra	Body	Rollover Sensor																																																										
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																										
K	2008	Sierra	Body	Theft Deterrent Module																									V	V	V	V																														
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Yukon	Chassis	Electronic Brake Control Module																																																										
K	2008	Yukon	Chassis	Electronic Suspension Control																																																										
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																										
K	2008	Yukon	Body	Amplifier (Bose)																																																										
K	2008	Yukon	Body	Assist Step Controller																																																										
K	2008	Yukon	Body	Body Control Module																																																										
K	2008	Yukon	Body	Body Control Module (aux.)																																																										
K	2008	Yukon	Body	Digital Radio Receiver																																																										
K	2008	Yukon	Body	Driver Door Switch																																																										
K	2008	Yukon	Body	HVAC Control Module Auto																																																										
K	2008	Yukon	Body	HVAC Control Module Manual																																																										
K	2008	Yukon	Body	Instrument Panel Cluster																																																										
K	2008	Yukon	Body	Lift Gate Module																																																										
K	2008	Yukon	Body	Memory Seat Module																																																										
K	2008	Yukon	Body	Park Assist Module																																																										
K	2008	Yukon	Body	Passenger Door Switch																																																										
K	2008	Yukon	Body	Passenger Presence System																																																										
K	2008	Yukon	Body	Radio																																																										
K	2008	Yukon	Body	Rear Heated Seat Module																																																										
K	2008	Yukon	Body	Rear HVAC/RSA																																																										
K	2008	Yukon	Body	Rollover Sensor																																																										
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																																										
K	2008	Yukon	Body	Theft Deterrent Module																									V	V	V	V																														
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																V										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																											
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																											
K	2008	Yukon Hybrid	Body	Body Control Module																																																											
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																											
K	2008	Yukon Hybrid	Body	Driver Door Switch																																																											
K	2008	Yukon Hybrid	Body	HVAC Control Module																																																											
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
K	2008	Yukon Hybrid	Body	Lift Gate Module																																																											
K	2008	Yukon Hybrid	Body	Memory Seat Module																																																											
K	2008	Yukon Hybrid	Body	Park Assist Module																																																											
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																																											
K	2008	Yukon Hybrid	Body	Passenger Presence System																																																											
K	2008	Yukon Hybrid	Body	Radio																																																											
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																											
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																										V	V	V	V																														
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																									
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																									
K	2008	Yukon XL	Body	Amplifier (Bose)																																																									
K	2008	Yukon XL	Body	Assist Step Controller																																																									
K	2008	Yukon XL	Body	Body Control Module																																																									
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																									
K	2008	Yukon XL	Body	Digital Radio Receiver																																																									
K	2008	Yukon XL	Body	Driver Door Switch																																																									
K	2008	Yukon XL	Body	HVAC Control Module Auto																																																									
K	2008	Yukon XL	Body	HVAC Control Module Manual																																																									
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																									
K	2008	Yukon XL	Body	Lift Gate Module																																																									
K	2008	Yukon XL	Body	Memory Seat Module																																																									
K	2008	Yukon XL	Body	Park Assist Module																																																									
K	2008	Yukon XL	Body	Passenger Door Switch																																																									
K	2008	Yukon XL	Body	Passenger Presence System																																																									
K	2008	Yukon XL	Body	Radio																																																									
K	2008	Yukon XL	Body	Rear Heated Seat Module																																																									
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																									
K	2008	Yukon XL	Body	Rollover Sensor																																																									
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
K	2008	Yukon XL	Body	Theft Deterrent Module																										V	V	V	V																												
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																									
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																									
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul																																																									
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																									
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																									
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																									
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																									
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																									
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																									
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2009	Sierra	Chassis	Electronic Suspension Control																																																										
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2009	Sierra	Body	Amplifier (Bose)																																																										
K	2009	Sierra	Body	Body Control Module																																																										
K	2009	Sierra	Body	Body Control Module (aux.)																																																										
K	2009	Sierra	Body	Digital Radio Receiver																																																										
K	2009	Sierra	Body	Driver Door Switch																																																										
K	2009	Sierra	Body	HVAC Control Module Auto																																																										
K	2009	Sierra	Body	HVAC Control Module Manual																																																										
K	2009	Sierra	Body	Instrument Panel Cluster																																																										
K	2009	Sierra	Body	Memory Seat Module																																																										
K	2009	Sierra	Body	Park Assist Module																																																										
K	2009	Sierra	Body	Passenger Door Switch																																																										
K	2009	Sierra	Body	Passenger Presence System																																																										
K	2009	Sierra	Body	Radio																																																										
K	2009	Sierra	Body	Rear Heated Seat Module																																																										
K	2009	Sierra	Body	Rear HVAC/RSA																																																										
K	2009	Sierra	Body	Rollover Sensor																																																										
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2009	Sierra	Body	Theft Deterrent Module																									V	V	V	V																														
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Sierra Hybrid	Body	Body Control Module																																																										
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Sierra Hybrid	Body	Driver Door Switch																																																										
K	2009	Sierra Hybrid	Body	HVAC Control Module																																																										
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Sierra Hybrid	Body	Memory Seat Module																																																										
K	2009	Sierra Hybrid	Body	Park Assist Module																																																										
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																																										
K	2009	Sierra Hybrid	Body	Passenger Presence System																																																										
K	2009	Sierra Hybrid	Body	Radio																																																										
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Sierra Hybrid	Body	Rollover Sensor																																																										
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Sierra Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Yukon	Chassis	Electronic Brake Control Module																																																										
K	2009	Yukon	Chassis	Electronic Suspension Control																																																										
K	2009	Yukon	Chassis	Trailer Brake Control Module																																																										
K	2009	Yukon	Body	Amplifier (Bose)																																																										
K	2009	Yukon	Body	Assist Step Controller																																																										
K	2009	Yukon	Body	Body Control Module																																																										
K	2009	Yukon	Body	Body Control Module (aux.)																																																										
K	2009	Yukon	Body	Digital Radio Receiver																																																										
K	2009	Yukon	Body	Driver Door Switch																																																										
K	2009	Yukon	Body	HVAC Control Module Auto																																																										
K	2009	Yukon	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2009	Yukon	Body	Instrument Panel Cluster																																																										
K	2009	Yukon	Body	Left Side Object Detection Module																																																										
K	2009	Yukon	Body	Lift Gate Module																																																										
K	2009	Yukon	Body	Memory Seat Module																																																										
K	2009	Yukon	Body	Park Assist Module																																																										
K	2009	Yukon	Body	Passenger Door Switch																																																										
K	2009	Yukon	Body	Passenger Presence System																																																										
K	2009	Yukon	Body	Radio																																																										
K	2009	Yukon	Body	Rear Heated Seat Module																																																										
K	2009	Yukon	Body	Rear HVAC/RSA																																																										
K	2009	Yukon	Body	Right Side Object Detection Module																																																										
K	2009	Yukon	Body	Rollover Sensor																																																										
K	2009	Yukon	Body	Supplemental Inflatable Restraint																																																										
K	2009	Yukon	Body	Theft Deterrent Module																										V	V	V	V																													
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																V									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Yukon Hybrid	Body	Body Control Module																																																										
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Yukon Hybrid	Body	Driver Door Switch																																																										
K	2009	Yukon Hybrid	Body	Heated Seat Module																																																										
K	2009	Yukon Hybrid	Body	HVAC Control Module																																																										
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
K	2009	Yukon Hybrid	Body	Park Assist Module																																																										
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																																										
K	2009	Yukon Hybrid	Body	Passenger Presence System																																																										
K	2009	Yukon Hybrid	Body	Radio																																																										
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
K	2009	Yukon Hybrid	Body	Rollover Sensor																																																										
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Yukon Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2009	Yukon XL	Body	Amplifier (Bose)																																																										
K	2009	Yukon XL	Body	Assist Step Controller																																																										
K	2009	Yukon XL	Body	Body Control Module																																																										
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2009	Yukon XL	Body	Digital Radio Receiver																																																										
K	2009	Yukon XL	Body	Driver Door Switch																																																										
K	2009	Yukon XL	Body	HVAC Control Module Auto																																																										
K	2009	Yukon XL	Body	HVAC Control Module Manual																																																										
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2009	Yukon XL	Body	Left Side Object Detection Module																																																										
K	2009	Yukon XL	Body	Lift Gate Module																																																										
K	2009	Yukon XL	Body	Memory Seat Module																																																										
K	2009	Yukon XL	Body	Park Assist Module																																																										
K	2009	Yukon XL	Body	Passenger Door Switch																																																										
K	2009	Yukon XL	Body	Passenger Presence System																																																										
K	2009	Yukon XL	Body	Radio																																																										
K	2009	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2009	Yukon XL	Body	Right Side Object Detection Module																																																										
K	2009	Yukon XL	Body	Rollover Sensor																																																										
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2009	Yukon XL	Body	Theft Deterrent Module																										V	V	V	V																												
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																										
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module										V																																															
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2010	Sierra	Chassis	Electronic Suspension Control																																																										
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra	Body	Amplifier (Bose)																																																										
K	2010	Sierra	Body	Body Control Module																																																									
K	2010	Sierra	Body	Body Control Module (aux.)																																																										
K	2010	Sierra	Body	Digital Radio Receiver																																																										
K	2010	Sierra	Body	Driver Door Switch																																																										
K	2010	Sierra	Body	HVAC Control Module Auto																																																										
K	2010	Sierra	Body	HVAC Control Module Manual																																																										
K	2010	Sierra	Body	Instrument Panel Cluster																																																										
K	2010	Sierra	Body	Memory Seat Module																																																										
K	2010	Sierra	Body	Park Assist Module																																																										
K	2010	Sierra	Body	Passenger Door Switch																																																										
K	2010	Sierra	Body	Passenger Presence System																																																										
K	2010	Sierra	Body	Radio																																																										
K	2010	Sierra	Body	Rear Heated Seat Module																																																										
K	2010	Sierra	Body	Rear HVAC/RSA																																																										
K	2010	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2010	Sierra	Body	Theft Deterrent Module																										V	V	V	V																													
K	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																															V									
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																							
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																							
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																						
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																						
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																						
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																						
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																						
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																						
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																						
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																						
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																						
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																						
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																						
K	2010	Sierra Hybrid	Body	Body Control Module																																																						
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																						
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																						
K	2010	Sierra Hybrid	Body	Driver Door Switch																																																						
K	2010	Sierra Hybrid	Body	Heated Seat Module																																																						
K	2010	Sierra Hybrid	Body	HVAC Control Module																																																						
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																						
K	2010	Sierra Hybrid	Body	Park Assist Module																																																						
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																																						
K	2010	Sierra Hybrid	Body	Passenger Presence System																																																						
K	2010	Sierra Hybrid	Body	Radio																																																						
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																						
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																						
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																						
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																						
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																									V	V	V	V																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																						
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																						
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																						
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																						
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																						
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																						
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																						
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																						
K	2010	Yukon	Chassis	Electronic Brake Control Module																																																						
K	2010	Yukon	Chassis	Electronic Suspension Control																																																						
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																						
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																						
K	2010	Yukon	Body	Amplifier (Bose)																																																					
K	2010	Yukon	Body	Assist Step Controller																																																					
K	2010	Yukon	Body	Body Control Module																																																					
K	2010	Yukon	Body	Body Control Module (aux.)																																																					
K	2010	Yukon	Body	Digital Radio Receiver																																																					
K	2010	Yukon	Body	Driver Door Switch																																																					
K	2010	Yukon	Body	HVAC Control Module Auto																																																					
K	2010	Yukon	Body	HVAC Control Module Manual																																																					

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2010	Yukon	Body	Instrument Panel Cluster																																																									
K	2010	Yukon	Body	Left Side Object Detection Module																																																									
K	2010	Yukon	Body	Lift Gate Module																																																									
K	2010	Yukon	Body	Memory Seat Module																																																									
K	2010	Yukon	Body	Park Assist Module																																																									
K	2010	Yukon	Body	Passenger Door Switch																																																									
K	2010	Yukon	Body	Passenger Presence System																																																									
K	2010	Yukon	Body	Radio																																																									
K	2010	Yukon	Body	Rear Heated Seat Module																																																									
K	2010	Yukon	Body	Rear HVAC/RSA																																																									
K	2010	Yukon	Body	Right Side Object Detection Module																																																									
K	2010	Yukon	Body	Supplemental Inflatable Restraint																																																									
K	2010	Yukon	Body	Theft Deterrent Module																										V	V	V	V																												
K	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																									
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																									
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																															V										
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																									
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																									
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																									
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																									
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																									
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																									
K	2010	Yukon Hybrid	Body	Body Control Module																																																									
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																									
K	2010	Yukon Hybrid	Body	Driver Door Switch																																																									
K	2010	Yukon Hybrid	Body	Heated Seat Module																																																									
K	2010	Yukon Hybrid	Body	HVAC Control Module																																																									
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																									
K	2010	Yukon Hybrid	Body	Lift Gate Module																																																									
K	2010	Yukon Hybrid	Body	Park Assist Module																																																									
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																																									
K	2010	Yukon Hybrid	Body	Passenger Presence System																																																									
K	2010	Yukon Hybrid	Body	Radio																																																									
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																										V	V	V	V																												
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																										
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																										
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2010	Yukon XL	Body	Amplifier (Bose)																																																										
K	2010	Yukon XL	Body	Assist Step Controller																																																										
K	2010	Yukon XL	Body	Body Control Module																																																										
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2010	Yukon XL	Body	Digital Radio Receiver																																																										
K	2010	Yukon XL	Body	Driver Door Switch																																																										
K	2010	Yukon XL	Body	HVAC Control Module Auto																																																										
K	2010	Yukon XL	Body	HVAC Control Module Manual																																																										
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2010	Yukon XL	Body	Left Side Object Detection Module																																																										
K	2010	Yukon XL	Body	Lift Gate Module																																																										
K	2010	Yukon XL	Body	Memory Seat Module																																																										
K	2010	Yukon XL	Body	Park Assist Module																																																										
K	2010	Yukon XL	Body	Passenger Door Switch																																																										
K	2010	Yukon XL	Body	Passenger Presence System																																																										
K	2010	Yukon XL	Body	Radio																																																									
K	2010	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2010	Yukon XL	Body	Right Side Object Detection Module																																																										
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2010	Yukon XL	Body	Theft Deterrent Module																									V	V	V	V																													
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2004	ALL	Chassis	4WAL 3 Sensor																																																										
L	2004	ALL	Body	Body Control Module												V	V																																												

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2004	ALL	Body	Instrument Panel Cluster																																																											
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
L	2005	ALL	Chassis	4WAL 3 Sensor																																																											
L	2005	ALL	Body	Body Control Module												V	V																																													
L	2005	ALL	Body	Instrument Panel Cluster																																																											
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																											
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																											
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																											
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																											
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																											
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2010	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2010	Terrain	Body	Body Control Module																																																											
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2010	Terrain	Body	Passenger Presence Module																																																											
L	2010	Terrain	Body	Instrument Cluster																																																											
L	2010	Terrain	Body	Radio																																																											
L	2010	Terrain	Body	Multimedia Player Interface Module																																																											
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																																											
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2010	Terrain	Body	Liftgate Control Module																																																											
L	2010	Terrain	Body	Parking Assist Control Module																																																											
L	2010	Terrain	Body	Frontview Camera Module																																																											
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																																											
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																																											
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																											
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																											
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2011	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2011	Terrain	Body	Body Control Module																																																											
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2011	Terrain	Body	Passenger Presence Module																																																											
L	2011	Terrain	Body	Instrument Cluster																																																											
L	2011	Terrain	Body	Radio																																																											
L	2011	Terrain	Body	Multimedia Player Interface Module																																																											
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2011	Terrain	Body	Liftgate Control Module																																																										
L	2011	Terrain	Body	Parking Assist Control Module																																																										
L	2011	Terrain	Body	Frontview Camera Module																																																										
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																																										
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																										
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2012	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2012	Terrain	Body	Body Control Module																																																										
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2012	Terrain	Body	Passenger Presence Module																																																										
L	2012	Terrain	Body	Instrument Cluster																																																										
L	2012	Terrain	Body	Radio																																																										
L	2012	Terrain	Body	Multimedia Player Interface Module																																																										
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2012	Terrain	Body	Liftgate Control Module																																																										
L	2012	Terrain	Body	Parking Assist Control Module																																																										
L	2012	Terrain	Body	Frontview Camera Module																																																										
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																																										
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2013	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2013	Terrain	Chassis	Power Steering Control Module																																																										
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																																										
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2013	Terrain	Body	Passenger Presence Module																																																										
L	2013	Terrain	Body	Instrument Cluster																																																										
L	2013	Terrain	Body	Radio																																																										
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2013	Terrain	Body	Liftgate Control Module																																																										
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																										
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																										
L	2013	Terrain	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2013	Terrain	Body	Frontview Camera Module																																																											
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2014	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2014	Terrain	Chassis	Power Steering Control Module																																																											
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																																											
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2014	Terrain	Body	Passenger Presence Module																																																											
L	2014	Terrain	Body	Instrument Cluster																																																											
L	2014	Terrain	Body	Radio																																																											
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2014	Terrain	Body	Liftgate Control Module																																																											
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2014	Terrain	Body	Parking Assist Control Module																																																											
L	2014	Terrain	Body	Frontview Camera Module																																																											
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2015	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2015	Terrain	Chassis	Power Steering Control Module																																																											
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																																											
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2015	Terrain	Body	Passenger Presence Module																																																											
L	2015	Terrain	Body	Instrument Cluster																																																											
L	2015	Terrain	Body	Radio																																																											
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																																											
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2015	Terrain	Body	Liftgate Control Module																																																											
L	2015	Terrain	Body	Seat Memory Control Module																																																											
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2015	Terrain	Body	Parking Assist Control Module																																																											
L	2015	Terrain	Body	Frontview Camera Module																																																											
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2016	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2016	Terrain	Chassis	Power Steering Control Module																																																										
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																																										
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2016	Terrain	Body	Passenger Presence Module																																																										
L	2016	Terrain	Body	Instrument Cluster																																																										
L	2016	Terrain	Body	Radio																																																										
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																																										
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2016	Terrain	Body	Liftgate Control Module																																					V	V	V	V	V	V															
L	2016	Terrain	Body	Seat Memory Control Module																																																										
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																										
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																										
L	2016	Terrain	Body	Parking Assist Control Module																																																										
L	2016	Terrain	Body	Frontview Camera Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
M	2004	ALL	Chassis	4WAL 3 Sensor																																																										
M	2004	ALL	Body	Body Control Module												V	V																																												
M	2004	ALL	Body	Instrument Panel Cluster																																																										
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
M	2005	ALL	Chassis	4WAL 3 Sensor																																																										
M	2005	ALL	Body	Body Control Module												V	V																																												
M	2005	ALL	Body	Instrument Panel Cluster																																																										
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module										V																																															
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module										V																																															
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module										V																																															
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
P	2007	ALL	Body	Theft Deterrent Module																																																										
R	2007	ALL	Powertrain	Engine Control Module																																																										
R	2007	ALL	Powertrain	Transmission Control Module																																																										
R	2007	ALL	Chassis	Electronic Brake Control Module																																																										
R	2007	ALL	Body	Body Control Module																																																										
R	2007	ALL	Body	Digital Radio Receiver																																																										
R	2007	ALL	Body	Driver Door Switch																																																										
R	2007	ALL	Body	Head Up Display																																																										
R	2007	ALL	Body	Heated Seat Module																																																										
R	2007	ALL	Body	HVAC Control Module Auto																																																										
R	2007	ALL	Body	HVAC Control Module Manual																																																										
R	2007	ALL	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2007	ALL	Body	Lift Gate Module																																																										
R	2007	ALL	Body	Park Assist Module																																																										
R	2007	ALL	Body	Passenger Door Switch																																																										
R	2007	ALL	Body	Passenger Presence System																																																										
R	2007	ALL	Body	Radio																																																										
R	2007	ALL	Body	Rear HVAC/RSA																																																										
R	2007	ALL	Body	Rollover Sensor																																																										
R	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2007	ALL	Body	Theft Deterrent Module																									V	V	V	V																															
R	2008	ALL	Powertrain	Engine Control Module																																																										
R	2008	ALL	Powertrain	Transmission Control Module																																																										
R	2008	ALL	Chassis	Electronic Brake Control Module																																																										
R	2008	ALL	Body	Body Control Module																																																										
R	2008	ALL	Body	Digital Radio Receiver																																																										
R	2008	ALL	Body	Driver Door Switch																																																										
R	2008	ALL	Body	Head Up Display																																																										
R	2008	ALL	Body	Heated Seat Module																																																										
R	2008	ALL	Body	HVAC Control Module Auto																																																										
R	2008	ALL	Body	HVAC Control Module Manual																																																										
R	2008	ALL	Body	Instrument Panel Cluster																																																										
R	2008	ALL	Body	Lift Gate Module																																																										
R	2008	ALL	Body	Park Assist Module																																																										
R	2008	ALL	Body	Passenger Door Switch																																																										
R	2008	ALL	Body	Passenger Presence System																																																										
R	2008	ALL	Body	Radio																																																										
R	2008	ALL	Body	Rear HVAC/RSA																																																										
R	2008	ALL	Body	Rollover Sensor																																																										
R	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2008	ALL	Body	Theft Deterrent Module																									V	V	V	V																															
R	2009	ALL	Powertrain	Engine Control Module																																																										
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2009	ALL	Powertrain	Transmission Control Module																																																										
R	2009	ALL	Chassis	Electronic Brake Control Module																																																										
R	2009	ALL	Body	Body Control Module																																																										
R	2009	ALL	Body	Digital Radio Receiver																																																										
R	2009	ALL	Body	Driver Door Switch																																																										
R	2009	ALL	Body	Head Up Display																																																										
R	2009	ALL	Body	Heated Seat Module																																																										
R	2009	ALL	Body	HVAC Control Module Auto																																																										
R	2009	ALL	Body	HVAC Control Module Manual																																																										
R	2009	ALL	Body	Instrument Panel Cluster																																																										
R	2009	ALL	Body	Lift Gate Module																																																										
R	2009	ALL	Body	Park Assist Module																																																										
R	2009	ALL	Body	Passenger Door Switch																																																										
R	2009	ALL	Body	Passenger Presence System																																																										
R	2009	ALL	Body	Radio																																																										
R	2009	ALL	Body	Rear HVAC/RSA																																																										
R	2009	ALL	Body	Rollover Sensor																																																										
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2009	ALL	Body	Theft Deterrent Module																									V	V	V	V																															
R	2010	ALL	Powertrain	Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2010	ALL	Powertrain	Transmission Control Module																																																									
R	2010	ALL	Chassis	Electronic Brake Control Module																																																									
R	2010	ALL	Body	Body Control Module																																																									
R	2010	ALL	Body	Digital Radio Receiver																																																									
R	2010	ALL	Body	Driver Door Switch																																																									
R	2010	ALL	Body	Head Up Display																																																									
R	2010	ALL	Body	Heated Seat Module																																																									
R	2010	ALL	Body	HVAC Control Module Auto																																																									
R	2010	ALL	Body	HVAC Control Module Manual																																																									
R	2010	ALL	Body	Instrument Panel Cluster																																																									
R	2010	ALL	Body	Lift Gate Module																																																									
R	2010	ALL	Body	Park Assist Module																																																									
R	2010	ALL	Body	Passenger Door Switch																																																									
R	2010	ALL	Body	Passenger Presence System																																																									
R	2010	ALL	Body	Radio																																																									
R	2010	ALL	Body	Rear HVAC/RSA																																																									
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2010	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
R	2011	ALL	Powertrain	Engine Control Module																																																									
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2011	ALL	Powertrain	Transmission Control Module																																																									
R	2011	ALL	Chassis	Electronic Brake Control Module																																																									
R	2011	ALL	Body	Body Control Module																																																									
R	2011	ALL	Body	Digital Radio Receiver																																																									
R	2011	ALL	Body	Driver Door Switch																																																									
R	2011	ALL	Body	Head Up Display																																																									
R	2011	ALL	Body	Heated Seat Module																																																									
R	2011	ALL	Body	HVAC Control Module Auto																																																									
R	2011	ALL	Body	HVAC Control Module Manual																																																									
R	2011	ALL	Body	Instrument Panel Cluster																																																									
R	2011	ALL	Body	Lift Gate Module																																																									
R	2011	ALL	Body	Park Assist Module																																																									
R	2011	ALL	Body	Passenger Door Switch																																																									
R	2011	ALL	Body	Passenger Presence System																																																									
R	2011	ALL	Body	Radio																																																									
R	2011	ALL	Body	Rear HVAC/RSA																																																									
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2011	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
R	2012	ALL	Powertrain	Engine Control Module																																																									
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2012	ALL	Powertrain	Transmission Control Module																																																									
R	2012	ALL	Chassis	Electronic Brake Control Module																																																									
R	2012	ALL	Body	Body Control Module																																																									
R	2012	ALL	Body	Digital Radio Receiver																																																									
R	2012	ALL	Body	Driver Door Switch																																																									
R	2012	ALL	Body	Head Up Display																																																									
R	2012	ALL	Body	Heated Seat Module																																																									
R	2012	ALL	Body	HVAC Control Module Auto																																																									
R	2012	ALL	Body	HVAC Control Module Manual																																																									
R	2012	ALL	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2012	ALL	Body	Lift Gate Module																																																										
R	2012	ALL	Body	Park Assist Module																																																										
R	2012	ALL	Body	Passenger Door Switch																																																										
R	2012	ALL	Body	Passenger Presence System																																																										
R	2012	ALL	Body	Radio																																																										
R	2012	ALL	Body	Rear HVAC/RSA																																																										
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2012	ALL	Body	Theft Deterrent Module																										V	V	V	V																														
R	2013	ALL	Powertrain	Engine Control Module																																																										
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2013	ALL	Powertrain	Transmission Control Module																																																										
R	2013	ALL	Chassis	Electronic Brake Control Module																																																										
R	2013	ALL	Body	Body Control Module																																																										
R	2013	ALL	Body	Digital Radio Receiver																																																										
R	2013	ALL	Body	Driver Door Switch																																																										
R	2013	ALL	Body	Head Up Display																																																										
R	2013	ALL	Body	Heated Seat Module																																																										
R	2013	ALL	Body	HVAC Control Module Auto																																																										
R	2013	ALL	Body	HVAC Control Module Manual																																																										
R	2013	ALL	Body	Instrument Panel Cluster																																																										
R	2013	ALL	Body	Left Side Object Detection Module																																																										
R	2013	ALL	Body	Lift Gate Module																																																										
R	2013	ALL	Body	Park Assist Module																																																										
R	2013	ALL	Body	Passenger Door Switch																																																										
R	2013	ALL	Body	Passenger Presence System																																																										
R	2013	ALL	Body	Radio																																																										
R	2013	ALL	Body	Rear HVAC/RSA																																																										
R	2013	ALL	Body	Right Side Object Detection Module																																																										
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2013	ALL	Body	Theft Deterrent Module																										V	V	V	V																														
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2014	Acadia	Powertrain	Chassis Control Module																																																										
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
R	2014	Acadia	Chassis	Electronic Brake Control Module																																																										
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2014	Acadia	Body	Passenger Presence Module																																																										
R	2014	Acadia	Body	Instrument Cluster																																																										
R	2014	Acadia	Body	Head-Up Display Module																																																										
R	2014	Acadia	Body	Radio																																																										
R	2014	Acadia	Body	Rear Audio Control Module																																																										
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																										
R	2014	Acadia	Body	Personal Audio Link Control Module																																																										
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																										
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2014	Acadia	Body	Liftgate Control Module																																											V													
R	2014	Acadia	Body	Seat Memory Control Module	V	V	V																																																					
R	2014	Acadia	Body	Front Seat Heating Control Module																																																								
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																							
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																							
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																							
R	2014	Acadia	Body	Parking Assist Control Module																																																						
R	2014	Acadia	Body	Frontview Camera Module																																																						
R	2014	Acadia	Body	Theft Deterrent Module				V	V																																																		
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																						
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																						
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																						
R	2015	Acadia	Chassis	Electronic Brake Control Module																																																						
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																						
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																						
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
R	2015	Acadia	Body	Passenger Presence Module																																																						
R	2015	Acadia	Body	Instrument Cluster																																																						
R	2015	Acadia	Body	Head-Up Display Module																																																						
R	2015	Acadia	Body	Radio																																																						
R	2015	Acadia	Body	Rear Audio Control Module																																																						
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																						
R	2015	Acadia	Body	Personal Audio Link Control Module																																																						
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																						
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																						
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																						
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																						
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																						
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																						
R	2015	Acadia	Body	Liftgate Control Module																																											V													
R	2015	Acadia	Body	Seat Memory Control Module	V	V	V																																																					
R	2015	Acadia	Body	Front Seat Heating Control Module																																																						
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																						
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																						
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																						
R	2015	Acadia	Body	Parking Assist Control Module																																																						
R	2015	Acadia	Body	Frontview Camera Module																																																						
R	2015	Acadia	Body	Theft Deterrent Module				V	V																																																		
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																						
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																						
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																						
R	2016	Acadia	Chassis	Electronic Brake Control Module																																																						
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																						
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																						
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
R	2016	Acadia	Body	Passenger Presence Module																																																						
R	2016	Acadia	Body	Instrument Cluster																																																						
R	2016	Acadia	Body	Head-Up Display Module																																																						
R	2016	Acadia	Body	Radio																																																						
R	2016	Acadia	Body	Rear Audio Control Module																																																						
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																						

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
R	2016	Acadia	Body	Personal Audio Link Control Module																																																										
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																										
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Acadia	Body	Liftgate Control Module																																											V															
R	2016	Acadia	Body	Seat Memory Control Module	V	V	V																																																							
R	2016	Acadia	Body	Front Seat Heating Control Module																																																										
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																										
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																										
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																										
R	2016	Acadia	Body	Parking Assist Control Module																																																										
R	2016	Acadia	Body	Frontview Camera Module																																																										
R	2016	Acadia	Body	Theft Deterrent Module				V	V																																																					
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																										
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Sonoma	Body	Body Control Module												V	V																																												
S	2004	Sonoma	Body	Instrument Panel Cluster																																																										
S	2004	Sonoma	Body	Base Radio																																																										
S	2004	Sonoma	Body	Uplevel Radio																																																										
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																										
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module											V																																															
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module											V																																															
S	2004	Canyon	Chassis	ABS Without Traction Control																																																										
S	2004	Canyon	Chassis	ABS With Traction Control																																																										
S	2004	Canyon	Body	Body Control Module																																																										
S	2004	Canyon	Body	Instrument Panel Cluster																																																										
S	2004	Canyon	Body	OnStar																																																										
S	2004	Canyon	Body	Base Radio																																																										
S	2004	Canyon	Body	Uplevel Radio																																																										
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																															
S	2004	Envoy	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy	Body	Amplifier (Bose)																																																										
S	2004	Envoy	Body	Body Control Module																																																										
S	2004	Envoy	Body	Driver Door Module																																																										
S	2004	Envoy	Body	Driver Seat Module																																																										
S	2004	Envoy	Body	Heating and Air Conditioning Auto																																																										
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy	Body	Instrument Panel Cluster																																																										
S	2004	Envoy	Body	Lift Gate Module																																																										
S	2004	Envoy	Body	OnStar																																																										
S	2004	Envoy	Body	Passenger Door Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2004	Envoy	Body	Uplevel Radio																																																									
S	2004	Envoy	Body	Navigation Radio																																																									
S	2004	Envoy	Body	Rear Seat Audio																																																									
S	2004	Envoy	Body	Rear Seat Entertainment																																																									
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																																									
S	2004	Envoy	Body	Vehicle Theft Deterrent																																																									
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																									
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module											V																																														
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																									
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																									
S	2004	Envoy XL	Body	Amplifier (Bose)																																																									
S	2004	Envoy XL	Body	Body Control Module																																																									
S	2004	Envoy XL	Body	Driver Door Module																																																									
S	2004	Envoy XL	Body	Driver Seat Module																																																									
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																									
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																									
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																									
S	2004	Envoy XL	Body	Lift Gate Module																																																									
S	2004	Envoy XL	Body	OnStar																																																									
S	2004	Envoy XL	Body	Passenger Door Module																																																									
S	2004	Envoy XL	Body	Uplevel Radio																																																									
S	2004	Envoy XL	Body	Navigation Radio																																																									
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																									
S	2004	Envoy XL	Body	Rear HVAC Manual																																																									
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																									
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																									
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																									
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																									
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module											V																																														
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																									
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																									
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																									
S	2004	Envoy XUV	Body	Body Control Module																																																									
S	2004	Envoy XUV	Body	Driver Door Module																																																									
S	2004	Envoy XUV	Body	Driver Seat Module																																																									
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																									
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																									
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																									
S	2004	Envoy XUV	Body	Lift Gate Module																																																									
S	2004	Envoy XUV	Body	OnStar																																																									
S	2004	Envoy XUV	Body	Passenger Door Module																																																									
S	2004	Envoy XUV	Body	Uplevel Radio																																																									
S	2004	Envoy XUV	Body	Navigation Radio																																																									
S	2004	Envoy XUV	Body	Rear Seat Audio																																																									
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																								
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																								
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																													
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																								
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																								
S	2004	Jimmy	Body	Body Control Module												V	V																																											
S	2004	Jimmy	Body	Heating and Air Conditioning																																																								
S	2004	Jimmy	Body	Instrument Panel Cluster																																																								
S	2004	Jimmy	Body	Memory Seat Module																																																								
S	2004	Jimmy	Body	Base Radio																																																								
S	2004	Jimmy	Body	Uplevel Radio																																																								
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																								
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																								
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module											V																																													
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																								
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module											V																																													
S	2005	Canyon	Chassis	ABS Without Traction Control																																																								
S	2005	Canyon	Chassis	ABS With Traction Control																																																								
S	2005	Canyon	Body	Body Control Module																																																								
S	2005	Canyon	Body	Instrument Panel Cluster																																																								
S	2005	Canyon	Body	Base Radio																																																								
S	2005	Canyon	Body	Uplevel Radio																																																								
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																																								
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																																								
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																													
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
S	2005	Envoy	Chassis	ABS Without Traction Control																																																								
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																								
S	2005	Envoy	Body	Body Control Module																																																								
S	2005	Envoy	Body	Disc Player and Video Display																																																								
S	2005	Envoy	Body	Driver Door Module																																																								
S	2005	Envoy	Body	Driver Seat Module																																																								
S	2005	Envoy	Body	Heating and Air Conditioning Auto																																																								
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																																								
S	2005	Envoy	Body	Instrument Panel Cluster																																																								
S	2005	Envoy	Body	Lift Gate Module																																																								
S	2005	Envoy	Body	Passenger Door Module																																																								
S	2005	Envoy	Body	Passenger Presence System																																																								
S	2005	Envoy	Body	Uplevel Radio																																																								
S	2005	Envoy	Body	Navigation Radio																																																								
S	2005	Envoy	Body	Rear Seat Audio																																																								
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																																								
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																																								
S	2005	Envoy	Body	Vehicle Theft Deterrent																																																								
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																													
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy XL	Body	Body Control Module																																																										
S	2005	Envoy XL	Body	Disc Player and Video Display																																																										
S	2005	Envoy XL	Body	Driver Door Module																																																										
S	2005	Envoy XL	Body	Driver Seat Module																																																										
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy XL	Body	Instrument Panel Cluster																																																										
S	2005	Envoy XL	Body	Lift Gate Module																																																										
S	2005	Envoy XL	Body	Passenger Door Module																																																										
S	2005	Envoy XL	Body	Passenger Presence System																																																										
S	2005	Envoy XL	Body	Uplevel Radio																																																										
S	2005	Envoy XL	Body	Navigation Radio																																																										
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
S	2005	Envoy XL	Body	Rear HVAC Manual																																																										
S	2005	Envoy XL	Body	Rear Seat Audio																																																										
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																										
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy XUV	Body	Body Control Module																																																										
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																										
S	2005	Envoy XUV	Body	Driver Door Module																																																										
S	2005	Envoy XUV	Body	Driver Seat Module																																																										
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																										
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																																										
S	2005	Envoy XUV	Body	Lift Gate Module																																																										
S	2005	Envoy XUV	Body	Passenger Door Module																																																										
S	2005	Envoy XUV	Body	Passenger Presence System																																																										
S	2005	Envoy XUV	Body	Uplevel Radio																																																										
S	2005	Envoy XUV	Body	Navigation Radio																																																										
S	2005	Envoy XUV	Body	Rear Seat Audio																																																										
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																										
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Jimmy	Body	Body Control Module												V	V																																												
S	2005	Jimmy	Body	Heating and Air Conditioning																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2005	Jimmy	Body	Instrument Panel Cluster																																																										
S	2005	Jimmy	Body	Memory Seat Module																																																										
S	2005	Jimmy	Body	Base Radio																																																										
S	2005	Jimmy	Body	Uplevel Radio																																																										
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																										
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Sonoma	Body	Body Control Module												V	V																																												
S	2005	Sonoma	Body	Instrument Panel Cluster																																																										
S	2005	Sonoma	Body	Base Radio																																																										
S	2005	Sonoma	Body	Uplevel Radio																																																										
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																										
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module											V																																														
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module											V																																														
S	2006	Canyon	Chassis	ABS Without Traction Control																																																										
S	2006	Canyon	Chassis	ABS With Traction Control																																																										
S	2006	Canyon	Body	Body Control Module																																																										
S	2006	Canyon	Body	Instrument Panel Cluster																																																										
S	2006	Canyon	Body	Passenger Presence System																																																										
S	2006	Canyon	Body	Base Radio																																																										
S	2006	Canyon	Body	Uplevel Radio																																																										
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2006	Envoy	Chassis	ABS/TCS/VSES																																																										
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																										
S	2006	Envoy	Body	Body Control Module																																																										
S	2006	Envoy	Body	Disc Player and Video Display																																																										
S	2006	Envoy	Body	Driver Door Module																																																										
S	2006	Envoy	Body	Driver Seat Module																																																										
S	2006	Envoy	Body	Heating and Air Conditioning Auto																																																										
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2006	Envoy	Body	Instrument Panel Cluster																																																										
S	2006	Envoy	Body	Lift Gate Module																																																										
S	2006	Envoy	Body	Passenger Door Module																																																										
S	2006	Envoy	Body	Passenger Presence System																																																										
S	2006	Envoy	Body	Uplevel Radio																																																										
S	2006	Envoy	Body	Navigation Radio																																																										
S	2006	Envoy	Body	Rear Seat Audio																																																										
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2006	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																									
S	2006	Envoy XL	Body	Body Control Module																																																								
S	2006	Envoy XL	Body	Disc Player and Video Display																																																								
S	2006	Envoy XL	Body	Driver Door Module																																																								
S	2006	Envoy XL	Body	Driver Seat Module																																																								
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																								
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																								
S	2006	Envoy XL	Body	Instrument Panel Cluster																																																								
S	2006	Envoy XL	Body	Lift Gate Module																																																								
S	2006	Envoy XL	Body	Passenger Door Module																																																								
S	2006	Envoy XL	Body	Passenger Presence System																																																								
S	2006	Envoy XL	Body	Uplevel Radio																																																								
S	2006	Envoy XL	Body	Navigation Radio																																																								
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																								
S	2006	Envoy XL	Body	Rear HVAC Manual																																																								
S	2006	Envoy XL	Body	Rear Seat Audio																																																								
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																								
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																								
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																								
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																			
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module											V																																														
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																			
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module											V																																														
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																								
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																								
S	2007	Canyon	Body	Body Control Module																																																								
S	2007	Canyon	Body	Digital Radio Receiver																																																								
S	2007	Canyon	Body	Generator Battery Control Module																																																								
S	2007	Canyon	Body	Instrument Panel Cluster																																																								
S	2007	Canyon	Body	Passenger Presence System																																																								
S	2007	Canyon	Body	Base Radio																																																								
S	2007	Canyon	Body	Uplevel Radio																																																								
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																																								
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																																								
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																			
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																						V																																			
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module											V																																														
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
S	2007	Envoy	Chassis	Electronic Brake Control Module																																																								
S	2007	Envoy	Body	Body Control Module																																																								
S	2007	Envoy	Body	Digital Radio Receiver																																																								
S	2007	Envoy	Body	Disc Player and Video Display																																																								
S	2007	Envoy	Body	Driver Door Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2007	Envoy	Body	Driver Seat Module																																																										
S	2007	Envoy	Body	Generator Battery Control Module																																																										
S	2007	Envoy	Body	HVAC Control Module Auto																																																										
S	2007	Envoy	Body	HVAC Control Module Manual																																																										
S	2007	Envoy	Body	Instrument Panel Cluster																																																										
S	2007	Envoy	Body	Lift Gate Module																																																										
S	2007	Envoy	Body	Passenger Door Module																																																										
S	2007	Envoy	Body	Passenger Presence System																																																										
S	2007	Envoy	Body	Uplevel Radio																																																										
S	2007	Envoy	Body	Navigation Radio																																																										
S	2007	Envoy	Body	Rear Seat Audio																																																										
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2007	Envoy	Body	Theft Deterrent Module																																																										
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																																										
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																										
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																										
S	2008	Canyon	Body	Body Control Module																																																										
S	2008	Canyon	Body	Digital Radio Receiver																																																										
S	2008	Canyon	Body	Generator Battery Control Module																																																										
S	2008	Canyon	Body	Instrument Panel Cluster																																																										
S	2008	Canyon	Body	Passenger Presence System																																																										
S	2008	Canyon	Body	Base Radio																																																										
S	2008	Canyon	Body	Uplevel Radio																																																										
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2008	Canyon	Body	Theft Deterrent Module																																																										
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2008	Envoy	Chassis	Electronic Brake Control Module																																																										
S	2008	Envoy	Body	Body Control Module																																																										
S	2008	Envoy	Body	Digital Radio Receiver																																																										
S	2008	Envoy	Body	Disc Player and Video Display																																																										
S	2008	Envoy	Body	Driver Door Module																																																										
S	2008	Envoy	Body	Driver Seat Module																																																										
S	2008	Envoy	Body	Generator Battery Control Module																																																										
S	2008	Envoy	Body	HVAC Control Module Auto																																																										
S	2008	Envoy	Body	HVAC Control Module Manual																																																										
S	2008	Envoy	Body	Instrument Panel Cluster																																																										
S	2008	Envoy	Body	Lift Gate Module																																																										
S	2008	Envoy	Body	Passenger Door Module																																																										
S	2008	Envoy	Body	Passenger Presence System																																																										
S	2008	Envoy	Body	Uplevel Radio																																																										
S	2008	Envoy	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2008	Envoy	Body	Rear Seat Audio																																																										
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2008	Envoy	Body	Theft Deterrent Module																																																										
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																																										
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																										
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
S	2009	Canyon	Chassis	Electronic Brake Control Module																																																										
S	2009	Canyon	Body	Body Control Module																																																										
S	2009	Canyon	Body	Digital Radio Receiver																																																										
S	2009	Canyon	Body	Generator Battery Control Module																																																										
S	2009	Canyon	Body	Instrument Panel Cluster																																																										
S	2009	Canyon	Body	Passenger Presence System																																																										
S	2009	Canyon	Body	Base Radio																																																										
S	2009	Canyon	Body	Uplevel Radio																																																										
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2009	Canyon	Body	Theft Deterrent Module																																																										
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																										
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																										
S	2009	Envoy	Chassis	Electronic Brake Control Module																																																										
S	2009	Envoy	Body	Body Control Module																																																										
S	2009	Envoy	Body	Digital Radio Receiver																																																										
S	2009	Envoy	Body	Disc Player and Video Display																																																										
S	2009	Envoy	Body	Driver Door Module																																																										
S	2009	Envoy	Body	Driver Seat Module																																																										
S	2009	Envoy	Body	Generator Battery Control Module																																																										
S	2009	Envoy	Body	HVAC Control Module Auto																																																										
S	2009	Envoy	Body	HVAC Control Module Manual																																																										
S	2009	Envoy	Body	Instrument Panel Cluster																																																										
S	2009	Envoy	Body	Lift Gate Module																																																										
S	2009	Envoy	Body	Passenger Door Module																																																										
S	2009	Envoy	Body	Passenger Presence System																																																										
S	2009	Envoy	Body	Uplevel Radio																																																										
S	2009	Envoy	Body	Navigation Radio																																																										
S	2009	Envoy	Body	Rear Seat Audio																																																										
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2009	Envoy	Body	Theft Deterrent Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																					
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2010	ALL	Chassis	Electronic Brake Control Module																																																										
S	2010	ALL	Body	Body Control Module																																																									
S	2010	ALL	Body	Digital Radio Receiver																																																									
S	2010	ALL	Body	Generator Battery Control Module																																																									
S	2010	ALL	Body	Instument Panel Cluster																																																									
S	2010	ALL	Body	Passenger Presence System																																																									
S	2010	ALL	Body	Personal Audio Link Module																																																									
S	2010	ALL	Body	Base Radio																																																									
S	2010	ALL	Body	Uplevel Radio																																																									
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
S	2010	ALL	Body	Theft Deterrent Module																																																									
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																									
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Sonoma	Body	Body Control Module												V	V																																											
T	2004	Sonoma	Body	Instrument Panel Cluster																																																									
T	2004	Sonoma	Body	Base Radio																																																									
T	2004	Sonoma	Body	Uplevel Radio																																																									
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																									
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module											V																																														
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module											V																																														
T	2004	Canyon	Chassis	ABS Without Traction Control																																																									
T	2004	Canyon	Chassis	ABS With Traction Control																																																									
T	2004	Canyon	Body	Body Control Module																																																									
T	2004	Canyon	Body	Instrument Panel Cluster																																																									
T	2004	Canyon	Body	OnStar																																																									
T	2004	Canyon	Body	Base Radio																																																									
T	2004	Canyon	Body	Uplevel Radio																																																									
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																																									
T	2004	Canyon	Body	Instrument Panel Cluster																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																									
T	2004	Envoy	Chassis	ABS Without Traction Control																																																									
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Envoy	Body	Amplifier (Bose)																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2004	Envoy	Body	Body Control Module																																																									
T	2004	Envoy	Body	Driver Door Module																																																									
T	2004	Envoy	Body	Driver Seat Module																																																									
T	2004	Envoy	Body	Heating and Air Conditioning Auto																																																									
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																																									
T	2004	Envoy	Body	Instrument Panel Cluster																																																									
T	2004	Envoy	Body	Lift Gate Module																																																									
T	2004	Envoy	Body	OnStar																																																									
T	2004	Envoy	Body	Passenger Door Module																																																									
T	2004	Envoy	Body	Uplevel Radio																																																									
T	2004	Envoy	Body	Navigation Radio																																																									
T	2004	Envoy	Body	Rear Seat Audio																																																									
T	2004	Envoy	Body	Rear Seat Entertainment																																																									
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																																									
T	2004	Envoy	Body	Vehicle Theft Deterrent																																																									
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																									
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																									
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module											V																																														
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																									
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																									
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Envoy XL	Body	Amplifier (Bose)																																																									
T	2004	Envoy XL	Body	Body Control Module																																																									
T	2004	Envoy XL	Body	Driver Door Module																																																									
T	2004	Envoy XL	Body	Driver Seat Module																																																									
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																									
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																									
T	2004	Envoy XL	Body	Instrument Panel Cluster																																																									
T	2004	Envoy XL	Body	Lift Gate Module																																																									
T	2004	Envoy XL	Body	OnStar																																																									
T	2004	Envoy XL	Body	Passenger Door Module																																																									
T	2004	Envoy XL	Body	Uplevel Radio																																																									
T	2004	Envoy XL	Body	Navigation Radio																																																									
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																									
T	2004	Envoy XL	Body	Rear HVAC Manual																																																									
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																									
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																									
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																									
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																									
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																									
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module											V																																														
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																									
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																									
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2004	Envoy XUV	Body	Body Control Module																																																										
T	2004	Envoy XUV	Body	Driver Door Module																																																										
T	2004	Envoy XUV	Body	Driver Seat Module																																																										
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																										
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																																										
T	2004	Envoy XUV	Body	Lift Gate Module																																																										
T	2004	Envoy XUV	Body	OnStar																																																										
T	2004	Envoy XUV	Body	Passenger Door Module																																																										
T	2004	Envoy XUV	Body	Uplevel Radio																																																										
T	2004	Envoy XUV	Body	Navigation Radio																																																										
T	2004	Envoy XUV	Body	Rear Seat Audio																																																										
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																										
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																														
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																										
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Jimmy	Body	Body Control Module												V	V																																												
T	2004	Jimmy	Body	Heating and Air Conditioning																																																										
T	2004	Jimmy	Body	Instrument Panel Cluster																																																										
T	2004	Jimmy	Body	Memory Seat Module																																																										
T	2004	Jimmy	Body	Base Radio																																																										
T	2004	Jimmy	Body	Uplevel Radio																																																										
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																										
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module											V																																														
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module											V																																														
T	2005	Canyon	Chassis	ABS Without Traction Control																																																										
T	2005	Canyon	Chassis	ABS With Traction Control																																																										
T	2005	Canyon	Body	Body Control Module																																																										
T	2005	Canyon	Body	Instrument Panel Cluster																																																										
T	2005	Canyon	Body	Base Radio																																																										
T	2005	Canyon	Body	Uplevel Radio																																																										
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																																										
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2005	Envoy	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy	Body	Body Control Module																																																										
T	2005	Envoy	Body	Disc Player and Video Display																																																										
T	2005	Envoy	Body	Driver Door Module																																																										
T	2005	Envoy	Body	Driver Seat Module																																																										
T	2005	Envoy	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																																										
T	2005	Envoy	Body	Instrument Panel Cluster																																																										
T	2005	Envoy	Body	Lift Gate Module																																																										
T	2005	Envoy	Body	Passenger Door Module																																																										
T	2005	Envoy	Body	Passenger Presence System																																																										
T	2005	Envoy	Body	Uplevel Radio																																																										
T	2005	Envoy	Body	Navigation Radio																																																										
T	2005	Envoy	Body	Rear Seat Audio																																																										
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2005	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy XL	Body	Body Control Module																																																										
T	2005	Envoy XL	Body	Disc Player and Video Display																																																										
T	2005	Envoy XL	Body	Driver Door Module																																																										
T	2005	Envoy XL	Body	Driver Seat Module																																																										
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2005	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2005	Envoy XL	Body	Lift Gate Module																																																										
T	2005	Envoy XL	Body	Passenger Door Module																																																										
T	2005	Envoy XL	Body	Passenger Presence System																																																										
T	2005	Envoy XL	Body	Uplevel Radio																																																										
T	2005	Envoy XL	Body	Navigation Radio																																																										
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2005	Envoy XL	Body	Rear HVAC Manual																																																										
T	2005	Envoy XL	Body	Rear Seat Audio																																																										
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																										
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																														
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy XUV	Body	Body Control Module																																																										
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																										
T	2005	Envoy XUV	Body	Driver Door Module																																																										
T	2005	Envoy XUV	Body	Driver Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																											
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																											
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																																											
T	2005	Envoy XUV	Body	Lift Gate Module																																																											
T	2005	Envoy XUV	Body	Passenger Door Module																																																											
T	2005	Envoy XUV	Body	Passenger Presence System																																																											
T	2005	Envoy XUV	Body	Uplevel Radio																																																											
T	2005	Envoy XUV	Body	Navigation Radio																																																											
T	2005	Envoy XUV	Body	Rear Seat Audio																																																											
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																											
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																											
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																											
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																											
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																											
T	2005	Jimmy	Body	Body Control Module												V	V																																													
T	2005	Jimmy	Body	Heating and Air Conditioning																																																											
T	2005	Jimmy	Body	Instrument Panel Cluster																																																											
T	2005	Jimmy	Body	Memory Seat Module																																																											
T	2005	Jimmy	Body	Base Radio																																																											
T	2005	Jimmy	Body	Uplevel Radio																																																											
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																											
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module											V																																															
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																											
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																											
T	2005	Sonoma	Body	Body Control Module												V	V																																													
T	2005	Sonoma	Body	Instrument Panel Cluster																																																											
T	2005	Sonoma	Body	Base Radio																																																											
T	2005	Sonoma	Body	Uplevel Radio																																																											
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																											
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module											V																																															
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module											V																																															
T	2006	Canyon	Chassis	ABS Without Traction Control																																																											
T	2006	Canyon	Chassis	ABS With Traction Control																																																											
T	2006	Canyon	Body	Body Control Module																																																											
T	2006	Canyon	Body	Instrument Panel Cluster																																																											
T	2006	Canyon	Body	Passenger Presence System																																																											
T	2006	Canyon	Body	Base Radio																																																											
T	2006	Canyon	Body	Uplevel Radio																																																											
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																																											
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																																											
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																					
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																																
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																											
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2006	Envoy	Chassis	ABS/TCS/VSES																																																										
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																										
T	2006	Envoy	Body	Body Control Module																																																										
T	2006	Envoy	Body	Disc Player and Video Display																																																										
T	2006	Envoy	Body	Driver Door Module																																																										
T	2006	Envoy	Body	Driver Seat Module																																																										
T	2006	Envoy	Body	Heating and Air Conditioning Auto																																																										
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																																										
T	2006	Envoy	Body	Instrument Panel Cluster																																																										
T	2006	Envoy	Body	Lift Gate Module																																																										
T	2006	Envoy	Body	Passenger Door Module																																																										
T	2006	Envoy	Body	Passenger Presence System																																																										
T	2006	Envoy	Body	Uplevel Radio																																																										
T	2006	Envoy	Body	Navigation Radio																																																										
T	2006	Envoy	Body	Rear Seat Audio																																																										
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2006	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																				
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																															
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																										
T	2006	Envoy XL	Body	Body Control Module																																																										
T	2006	Envoy XL	Body	Disc Player and Video Display																																																										
T	2006	Envoy XL	Body	Driver Door Module																																																										
T	2006	Envoy XL	Body	Driver Seat Module																																																										
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2006	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2006	Envoy XL	Body	Lift Gate Module																																																										
T	2006	Envoy XL	Body	Passenger Door Module																																																										
T	2006	Envoy XL	Body	Passenger Presence System																																																										
T	2006	Envoy XL	Body	Uplevel Radio																																																										
T	2006	Envoy XL	Body	Navigation Radio																																																										
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2006	Envoy XL	Body	Rear HVAC Manual																																																										
T	2006	Envoy XL	Body	Rear Seat Audio																																																										
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																										
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module											V																																															
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module											V																																															
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																										
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																										
T	2007	Canyon	Body	Body Control Module																																																										
T	2007	Canyon	Body	Digital Radio Receiver																																																										
T	2007	Canyon	Body	Generator Battery Control Module																																																										
T	2007	Canyon	Body	Instrument Panel Cluster																																																										
T	2007	Canyon	Body	Passenger Presence System																																																										
T	2007	Canyon	Body	Base Radio																																																										
T	2007	Canyon	Body	Uplevel Radio																																																										
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																					
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module											V																																															
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																						V																																				
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module											V																																															
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																										
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																										
T	2007	Envoy	Chassis	Electronic Brake Control Module																																																										
T	2007	Envoy	Body	Body Control Module																																																										
T	2007	Envoy	Body	Digital Radio Receiver																																																										
T	2007	Envoy	Body	Disc Player and Video Display																																																										
T	2007	Envoy	Body	Driver Door Module																																																										
T	2007	Envoy	Body	Driver Seat Module																																																										
T	2007	Envoy	Body	Generator Battery Control Module																																																										
T	2007	Envoy	Body	HVAC Control Module Auto																																																										
T	2007	Envoy	Body	HVAC Control Module Manual																																																										
T	2007	Envoy	Body	Instrument Panel Cluster																																																										
T	2007	Envoy	Body	Lift Gate Module																																																										
T	2007	Envoy	Body	Passenger Door Module																																																										
T	2007	Envoy	Body	Passenger Presence System																																																										
T	2007	Envoy	Body	Uplevel Radio																																																										
T	2007	Envoy	Body	Navigation Radio																																																										
T	2007	Envoy	Body	Rear Seat Audio																																																										
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2007	Envoy	Body	Theft Deterrent Module																																																										
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2008	Canyon	Body	Body Control Module																																																											
T	2008	Canyon	Body	Digital Radio Receiver																																																											
T	2008	Canyon	Body	Generator Battery Control Module																																																											
T	2008	Canyon	Body	Instrument Panel Cluster																																																											
T	2008	Canyon	Body	Passenger Presence System																																																											
T	2008	Canyon	Body	Base Radio																																																											
T	2008	Canyon	Body	Uplevel Radio																																																											
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																																											
T	2008	Canyon	Body	Theft Deterrent Module																																																											
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																																											
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																						
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2008	Envoy	Chassis	Electronic Brake Control Module																																																												
T	2008	Envoy	Body	Body Control Module																																																											
T	2008	Envoy	Body	Digital Radio Receiver																																																											
T	2008	Envoy	Body	Disc Player and Video Display																																																											
T	2008	Envoy	Body	Driver Door Module																																																											
T	2008	Envoy	Body	Driver Seat Module																																																											
T	2008	Envoy	Body	Generator Battery Control Module																																																											
T	2008	Envoy	Body	HVAC Control Module Auto																																																											
T	2008	Envoy	Body	HVAC Control Module Manual																																																											
T	2008	Envoy	Body	Instrument Panel Cluster																																																											
T	2008	Envoy	Body	Lift Gate Module																																																											
T	2008	Envoy	Body	Passenger Door Module																																																											
T	2008	Envoy	Body	Passenger Presence System																																																											
T	2008	Envoy	Body	Uplevel Radio																																																											
T	2008	Envoy	Body	Navigation Radio																																																											
T	2008	Envoy	Body	Rear Seat Audio																																																											
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																																											
T	2008	Envoy	Body	Theft Deterrent Module																																																											
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																																											
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																						
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																						
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																											
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																											
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																											
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																											
T	2009	Canyon	Chassis	Electronic Brake Control Module																																																											
T	2009	Canyon	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2009	Canyon	Body	Digital Radio Receiver																																																										
T	2009	Canyon	Body	Generator Battery Control Module																																																										
T	2009	Canyon	Body	Instrument Panel Cluster																																																										
T	2009	Canyon	Body	Passenger Presence System																																																										
T	2009	Canyon	Body	Base Radio																																																										
T	2009	Canyon	Body	Uplevel Radio																																																										
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2009	Canyon	Body	Theft Deterrent Module																																																										
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																						V																																						
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																											
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																											
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																											
T	2009	Envoy	Body	Body Control Module																																																										
T	2009	Envoy	Body	Digital Radio Receiver																																																										
T	2009	Envoy	Body	Disc Player and Video Display																																																										
T	2009	Envoy	Body	Driver Door Module																																																										
T	2009	Envoy	Body	Driver Seat Module																																																										
T	2009	Envoy	Body	Generator Battery Control Module																																																										
T	2009	Envoy	Body	HVAC Control Module Auto																																																										
T	2009	Envoy	Body	HVAC Control Module Manual																																																										
T	2009	Envoy	Body	Instrument Panel Cluster																																																										
T	2009	Envoy	Body	Lift Gate Module																																																										
T	2009	Envoy	Body	Passenger Door Module																																																										
T	2009	Envoy	Body	Passenger Presence System																																																										
T	2009	Envoy	Body	Uplevel Radio																																																										
T	2009	Envoy	Body	Navigation Radio																																																										
T	2009	Envoy	Body	Rear Seat Audio																																																										
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2009	Envoy	Body	Theft Deterrent Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																						
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																						
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
T	2010	ALL	Chassis	Electronic Brake Control Module																																																											
T	2010	ALL	Body	Body Control Module																																																										
T	2010	ALL	Body	Digital Radio Receiver																																																										
T	2010	ALL	Body	Generator Battery Control Module																																																										
T	2010	ALL	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
T	2010	ALL	Body	Passenger Presence System																																																										
T	2010	ALL	Body	Personal Audio Link Module																																																										
T	2010	ALL	Body	Base Radio																																																										
T	2010	ALL	Body	Uplevel Radio																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Theft Deterrent Module																																																										
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																										
V	2007	ALL	Powertrain	Engine Control Module																																																										
V	2007	ALL	Powertrain	Rear Drive System																																																										
V	2007	ALL	Powertrain	Transmission Control Module																																																										
V	2007	ALL	Chassis	Electronic Brake Control Module																																																										
V	2007	ALL	Body	Body Control Module																																																										
V	2007	ALL	Body	Digital Radio Receiver																																																										
V	2007	ALL	Body	Driver Door Switch																																																										
V	2007	ALL	Body	Head Up Display																																																										
V	2007	ALL	Body	Heated Seat Module																																																										
V	2007	ALL	Body	HVAC Control Module Auto																																																										
V	2007	ALL	Body	HVAC Control Module Manual																																																										
V	2007	ALL	Body	Instrument Panel Cluster																																																										
V	2007	ALL	Body	Lift Gate Module																																																										
V	2007	ALL	Body	Park Assist Module																																																										
V	2007	ALL	Body	Passenger Door Switch																																																										
V	2007	ALL	Body	Passenger Presence System																																																										
V	2007	ALL	Body	Radio																																																										
V	2007	ALL	Body	Rear HVAC/RSA																																																										
V	2007	ALL	Body	Rollover Sensor																																																										
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2007	ALL	Body	Theft Deterrent Module																									V	V	V	V																														
V	2008	ALL	Powertrain	Engine Control Module																																																										
V	2008	ALL	Powertrain	Rear Drive System																																																										
V	2008	ALL	Powertrain	Transmission Control Module																																																										
V	2008	ALL	Chassis	Electronic Brake Control Module																																																										
V	2008	ALL	Body	Body Control Module																																																										
V	2008	ALL	Body	Digital Radio Receiver																																																										
V	2008	ALL	Body	Driver Door Switch																																																										
V	2008	ALL	Body	Head Up Display																																																										
V	2008	ALL	Body	Heated Seat Module																																																										
V	2008	ALL	Body	HVAC Control Module Auto																																																										
V	2008	ALL	Body	HVAC Control Module Manual																																																										
V	2008	ALL	Body	Instrument Panel Cluster																																																										
V	2008	ALL	Body	Lift Gate Module																																																										
V	2008	ALL	Body	Park Assist Module																																																										
V	2008	ALL	Body	Passenger Door Switch																																																										
V	2008	ALL	Body	Passenger Presence System																																																										
V	2008	ALL	Body	Radio																																																										
V	2008	ALL	Body	Rear HVAC/RSA																																																										
V	2008	ALL	Body	Rollover Sensor																																																										
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2008	ALL	Body	Theft Deterrent Module																									V	V	V	V																														
V	2009	ALL	Powertrain	Engine Control Module																																																										
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
V	2009	ALL	Powertrain	Rear Drive System																																																									
V	2009	ALL	Powertrain	Transmission Control Module																																																									
V	2009	ALL	Chassis	Electronic Brake Control Module																																																									
V	2009	ALL	Body	Body Control Module																																																									
V	2009	ALL	Body	Digital Radio Receiver																																																									
V	2009	ALL	Body	Driver Door Switch																																																									
V	2009	ALL	Body	Head Up Display																																																									
V	2009	ALL	Body	Heated Seat Module																																																									
V	2009	ALL	Body	HVAC Control Module Auto																																																									
V	2009	ALL	Body	HVAC Control Module Manual																																																									
V	2009	ALL	Body	Instrument Panel Cluster																																																									
V	2009	ALL	Body	Lift Gate Module																																																									
V	2009	ALL	Body	Park Assist Module																																																									
V	2009	ALL	Body	Passenger Door Switch																																																									
V	2009	ALL	Body	Passenger Presence System																																																									
V	2009	ALL	Body	Radio																																																									
V	2009	ALL	Body	Rear HVAC/RSA																																																									
V	2009	ALL	Body	Rollover Sensor																																																									
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2009	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
V	2010	ALL	Powertrain	Engine Control Module																																																									
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2010	ALL	Powertrain	Rear Drive System																																																									
V	2010	ALL	Powertrain	Transmission Control Module																																																									
V	2010	ALL	Chassis	Electronic Brake Control Module																																																									
V	2010	ALL	Body	Body Control Module																																																									
V	2010	ALL	Body	Digital Radio Receiver																																																									
V	2010	ALL	Body	Driver Door Switch																																																									
V	2010	ALL	Body	Head Up Display																																																									
V	2010	ALL	Body	Heated Seat Module																																																									
V	2010	ALL	Body	HVAC Control Module Auto																																																									
V	2010	ALL	Body	HVAC Control Module Manual																																																									
V	2010	ALL	Body	Instrument Panel Cluster																																																									
V	2010	ALL	Body	Lift Gate Module																																																									
V	2010	ALL	Body	Park Assist Module																																																									
V	2010	ALL	Body	Passenger Door Switch																																																									
V	2010	ALL	Body	Passenger Presence System																																																									
V	2010	ALL	Body	Radio																																																									
V	2010	ALL	Body	Rear HVAC/RSA																																																									
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2010	ALL	Body	Theft Deterrent Module																										V	V	V	V																												
V	2011	ALL	Powertrain	Engine Control Module																																																									
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2011	ALL	Powertrain	Rear Drive System																																																									
V	2011	ALL	Powertrain	Transmission Control Module																																																									
V	2011	ALL	Chassis	Electronic Brake Control Module																																																									
V	2011	ALL	Body	Body Control Module																																																									
V	2011	ALL	Body	Digital Radio Receiver																																																									
V	2011	ALL	Body	Driver Door Switch																																																									
V	2011	ALL	Body	Head Up Display																																																									
V	2011	ALL	Body	Heated Seat Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
V	2011	ALL	Body	HVAC Control Module Auto																																																										
V	2011	ALL	Body	HVAC Control Module Manual																																																										
V	2011	ALL	Body	Instrument Panel Cluster																																																										
V	2011	ALL	Body	Lift Gate Module																																																										
V	2011	ALL	Body	Park Assist Module																																																										
V	2011	ALL	Body	Passenger Door Switch																																																										
V	2011	ALL	Body	Passenger Presence System																																																										
V	2011	ALL	Body	Radio																																																										
V	2011	ALL	Body	Rear HVAC/RSA																																																										
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2011	ALL	Body	Theft Deterrent Module																										V	V	V	V																														
V	2012	ALL	Powertrain	Engine Control Module																																																										
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2012	ALL	Powertrain	Rear Drive System																																																										
V	2012	ALL	Powertrain	Transmission Control Module																																																										
V	2012	ALL	Chassis	Electronic Brake Control Module																																																										
V	2012	ALL	Body	Body Control Module																																																										
V	2012	ALL	Body	Digital Radio Receiver																																																										
V	2012	ALL	Body	Driver Door Switch																																																										
V	2012	ALL	Body	Head Up Display																																																										
V	2012	ALL	Body	Heated Seat Module																																																										
V	2012	ALL	Body	HVAC Control Module Auto																																																										
V	2012	ALL	Body	HVAC Control Module Manual																																																										
V	2012	ALL	Body	Instrument Panel Cluster																																																										
V	2012	ALL	Body	Lift Gate Module																																																										
V	2012	ALL	Body	Park Assist Module																																																										
V	2012	ALL	Body	Passenger Door Switch																																																										
V	2012	ALL	Body	Passenger Presence System																																																										
V	2012	ALL	Body	Radio																																																										
V	2012	ALL	Body	Rear HVAC/RSA																																																										
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2012	ALL	Body	Theft Deterrent Module																										V	V	V	V																														
V	2013	ALL	Powertrain	Engine Control Module																																																										
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2013	ALL	Powertrain	Rear Drive System																																																										
V	2013	ALL	Powertrain	Transmission Control Module																																																										
V	2013	ALL	Chassis	Electronic Brake Control Module																																																										
V	2013	ALL	Body	Body Control Module																																																										
V	2013	ALL	Body	Digital Radio Receiver																																																										
V	2013	ALL	Body	Driver Door Switch																																																										
V	2013	ALL	Body	Head Up Display																																																										
V	2013	ALL	Body	Heated Seat Module																																																										
V	2013	ALL	Body	HVAC Control Module Auto																																																										
V	2013	ALL	Body	HVAC Control Module Manual																																																										
V	2013	ALL	Body	Instrument Panel Cluster																																																										
V	2013	ALL	Body	Left Side Object Detection Module																																																										
V	2013	ALL	Body	Lift Gate Module																																																										
V	2013	ALL	Body	Park Assist Module																																																										
V	2013	ALL	Body	Passenger Door Switch																																																										
V	2013	ALL	Body	Passenger Presence System																																																										
V	2013	ALL	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
V	2013	ALL	Body	Rear HVAC/RSA																																																										
V	2013	ALL	Body	Right Side Object Detection Module																																																										
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2013	ALL	Body	Theft Deterrent Module																									V	V	V	V																														
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2014	Acadia	Powertrain	Chassis Control Module																																																										
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
V	2014	Acadia	Chassis	Electronic Brake Control Module																																																										
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2014	Acadia	Body	Passenger Presence Module																																																										
V	2014	Acadia	Body	Instrument Cluster																																																										
V	2014	Acadia	Body	Head-Up Display Module																																																										
V	2014	Acadia	Body	Radio																																																										
V	2014	Acadia	Body	Rear Audio Control Module																																																										
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																										
V	2014	Acadia	Body	Personal Audio Link Control Module																																																										
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																										
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
V	2014	Acadia	Body	Liftgate Control Module																																											V															
V	2014	Acadia	Body	Seat Memory Control Module	V	V	V																																																							
V	2014	Acadia	Body	Front Seat Heating Control Module																																																										
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																										
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																										
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																										
V	2014	Acadia	Body	Parking Assist Control Module																																																										
V	2014	Acadia	Body	Frontview Camera Module																																																										
V	2014	Acadia	Body	Theft Deterrent Module				V	V																																																					
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
V	2015	Acadia	Chassis	Electronic Brake Control Module																																																										
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2015	Acadia	Body	Passenger Presence Module																																																										
V	2015	Acadia	Body	Instrument Cluster																																																										
V	2015	Acadia	Body	Head-Up Display Module																																																										
V	2015	Acadia	Body	Radio																																																										
V	2015	Acadia	Body	Rear Audio Control Module																																																										
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																										
V	2015	Acadia	Body	Personal Audio Link Control Module																																																										
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																										
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																										
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																										
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
V	2015	Acadia	Body	Liftgate Control Module																																										V															
V	2015	Acadia	Body	Seat Memory Control Module	V	V	V																																																							
V	2015	Acadia	Body	Front Seat Heating Control Module																																																										
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																										
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																										
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																										
V	2015	Acadia	Body	Parking Assist Control Module																																																										
V	2015	Acadia	Body	Frontview Camera Module																																																										
V	2015	Acadia	Body	Theft Deterrent Module				V	V																																																					
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Acadia	Chassis	Electronic Brake Control Module																																																										
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Acadia	Body	Passenger Presence Module																																																										
V	2016	Acadia	Body	Instrument Cluster																																																										
V	2016	Acadia	Body	Head-Up Display Module																																																										
V	2016	Acadia	Body	Radio																																																										
V	2016	Acadia	Body	Rear Audio Control Module																																																										
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																										
V	2016	Acadia	Body	Personal Audio Link Control Module																																																										
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																										
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Acadia	Body	Liftgate Control Module																																										V															
V	2016	Acadia	Body	Seat Memory Control Module	V	V	V																																																								
V	2016	Acadia	Body	Front Seat Heating Control Module																																																										
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																										
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																										
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																										
V	2016	Acadia	Body	Parking Assist Control Module																																																										
V	2016	Acadia	Body	Frontview Camera Module																																																										
V	2016	Acadia	Body	Theft Deterrent Module				V	V																																																					
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																									
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module										V																																															
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																									
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																									
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																									
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																									
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																									
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
1	2011	Sierra	Chassis	Electronic Suspension Control																																																									
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																									
1	2011	Sierra	Body	Amplifier (Bose)																																																									
1	2011	Sierra	Body	Body Control Module																																																									
1	2011	Sierra	Body	Body Control Module (aux.)																																																									
1	2011	Sierra	Body	Digital Radio Receiver																																																									
1	2011	Sierra	Body	Driver Door Switch																																																									
1	2011	Sierra	Body	HVAC Control Module Auto																																																									
1	2011	Sierra	Body	HVAC Control Module Manual																																																									
1	2011	Sierra	Body	Instrument Panel Cluster																																																									
1	2011	Sierra	Body	Memory Seat Module																																																									
1	2011	Sierra	Body	Park Assist Module																																																									
1	2011	Sierra	Body	Passenger Door Switch																																																									
1	2011	Sierra	Body	Passenger Presence System																																																									
1	2011	Sierra	Body	Radio																																																									
1	2011	Sierra	Body	Rear Heated Seat Module																																																									
1	2011	Sierra	Body	Rear HVAC/RSA																																																									
1	2011	Sierra	Body	Supplemental Inflatable Restraint																																																									
1	2011	Sierra	Body	Theft Deterrent Module																										V	V	V	V																												
1	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																									
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																									
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																	V								
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																									
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																									
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																									
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																									
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																									
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																									
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																									
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																									
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																									
1	2011	Sierra Hybrid	Body	Body Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																									
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																									
1	2011	Sierra Hybrid	Body	Driver Door Switch																																																									
1	2011	Sierra Hybrid	Body	Heated Seat Module																																																									
1	2011	Sierra Hybrid	Body	HVAC Control Module																																																									
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																									
1	2011	Sierra Hybrid	Body	Park Assist Module																																																									
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																																									
1	2011	Sierra Hybrid	Body	Passenger Presence System																																																									
1	2011	Sierra Hybrid	Body	Radio																																																									
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																									
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																									
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																									
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																									
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																										V	V	V	V																												
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2011	Yukon	Chassis	Electronic Brake Control Module																																																									
1	2011	Yukon	Chassis	Electronic Suspension Control																																																									
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																									
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																									
1	2011	Yukon	Body	Amplifier (Bose)																																																									
1	2011	Yukon	Body	Assist Step Controller																																																									
1	2011	Yukon	Body	Body Control Module																																																									
1	2011	Yukon	Body	Body Control Module (aux.)																																																									
1	2011	Yukon	Body	Digital Radio Receiver																																																									
1	2011	Yukon	Body	Driver Door Switch																																																									
1	2011	Yukon	Body	HVAC Control Module Auto																																																									
1	2011	Yukon	Body	HVAC Control Module Manual																																																									
1	2011	Yukon	Body	Instrument Panel Cluster																																																									
1	2011	Yukon	Body	Left Side Object Detection Module																																																									
1	2011	Yukon	Body	Lift Gate Module																																																									
1	2011	Yukon	Body	Memory Seat Module																																																									
1	2011	Yukon	Body	Park Assist Module																																																									
1	2011	Yukon	Body	Passenger Door Switch																																																									
1	2011	Yukon	Body	Passenger Presence System																																																									
1	2011	Yukon	Body	Radio																																																									
1	2011	Yukon	Body	Rear Heated Seat Module																																																									
1	2011	Yukon	Body	Rear HVAC/RSA																																																									
1	2011	Yukon	Body	Right Side Object Detection Module																																																									
1	2011	Yukon	Body	Supplemental Inflatable Restraint																																																									
1	2011	Yukon	Body	Theft Deterrent Module																										V	V	V	V																												
1	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																									
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																									
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																	V								
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																									
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2011	Yukon Hybrid	Body	Body Control Module																																																										
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																										
1	2011	Yukon Hybrid	Body	HVAC Control Module																																																										
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
1	2011	Yukon Hybrid	Body	Lift Gate Module																																																										
1	2011	Yukon Hybrid	Body	Park Assist Module																																																										
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2011	Yukon Hybrid	Body	Passenger Presence System																																																										
1	2011	Yukon Hybrid	Body	Radio																																																										
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																									V	V	V	V																														
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																										
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon XL	Body	Amplifier (Bose)																																																										
1	2011	Yukon XL	Body	Assist Step Controller																																																										
1	2011	Yukon XL	Body	Body Control Module																																																										
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2011	Yukon XL	Body	Digital Radio Receiver																																																										
1	2011	Yukon XL	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2011	Yukon XL	Body	HVAC Control Module Auto																																																									
1	2011	Yukon XL	Body	HVAC Control Module Manual																																																									
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																									
1	2011	Yukon XL	Body	Left Side Object Detection Module																																																									
1	2011	Yukon XL	Body	Lift Gate Module																																																									
1	2011	Yukon XL	Body	Memory Seat Module																																																									
1	2011	Yukon XL	Body	Park Assist Module																																																									
1	2011	Yukon XL	Body	Passenger Door Switch																																																									
1	2011	Yukon XL	Body	Passenger Presence System																																																									
1	2011	Yukon XL	Body	Radio																																																									
1	2011	Yukon XL	Body	Rear Heated Seat Module																																																									
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																									
1	2011	Yukon XL	Body	Right Side Object Detection Module																																																									
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
1	2011	Yukon XL	Body	Theft Deterrent Module																										V	V	V	V																												
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																									
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module										V																																															
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																									
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																									
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																									
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																									
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																									
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
1	2012	Sierra	Chassis	Electronic Suspension Control																																																									
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																									
1	2012	Sierra	Body	Amplifier (Bose)																																																									
1	2012	Sierra	Body	Body Control Module																																																									
1	2012	Sierra	Body	Body Control Module (aux.)																																																									
1	2012	Sierra	Body	Digital Radio Receiver																																																									
1	2012	Sierra	Body	Driver Door Switch																																																									
1	2012	Sierra	Body	HVAC Control Module Auto																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2012	Sierra	Body	HVAC Control Module Manual																																																										
1	2012	Sierra	Body	Instrument Panel Cluster																																																										
1	2012	Sierra	Body	Memory Seat Module																																																										
1	2012	Sierra	Body	Park Assist Module																																																										
1	2012	Sierra	Body	Passenger Door Switch																																																										
1	2012	Sierra	Body	Passenger Presence System																																																										
1	2012	Sierra	Body	Radio																																																										
1	2012	Sierra	Body	Navigation Radio																																																										
1	2012	Sierra	Body	Rear Heated Seat Module																																																										
1	2012	Sierra	Body	Rear HVAC/RSA																																																										
1	2012	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2012	Sierra	Body	Theft Deterrent Module																										V	V	V	V																													
1	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																V									
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
1	2012	Sierra Hybrid	Body	Body Control Module																																																										
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2012	Sierra Hybrid	Body	Driver Door Switch																																																										
1	2012	Sierra Hybrid	Body	Heated Seat Module																																																										
1	2012	Sierra Hybrid	Body	HVAC Control Module																																																										
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2012	Sierra Hybrid	Body	Park Assist Module																																																										
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																																										
1	2012	Sierra Hybrid	Body	Passenger Presence System																																																										
1	2012	Sierra Hybrid	Body	Radio																																																										
1	2012	Sierra Hybrid	Body	Navigation Radio																																																										
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2012	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2012	Yukon	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																										
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Yukon	Body	Amplifier (Bose)																																																										
1	2012	Yukon	Body	Assist Step Controller																																																										
1	2012	Yukon	Body	Body Control Module																																																										
1	2012	Yukon	Body	Body Control Module (aux.)																																																										
1	2012	Yukon	Body	Digital Radio Receiver																																																										
1	2012	Yukon	Body	Driver Door Switch																																																										
1	2012	Yukon	Body	HVAC Control Module Auto																																																										
1	2012	Yukon	Body	HVAC Control Module Manual																																																										
1	2012	Yukon	Body	Instrument Panel Cluster																																																										
1	2012	Yukon	Body	Left Side Object Detection Module																																																										
1	2012	Yukon	Body	Lift Gate Module																																																										
1	2012	Yukon	Body	Memory Seat Module																																																										
1	2012	Yukon	Body	Park Assist Module																																																										
1	2012	Yukon	Body	Passenger Door Switch																																																										
1	2012	Yukon	Body	Passenger Presence System																																																										
1	2012	Yukon	Body	Radio																																																										
1	2012	Yukon	Body	Navigation Radio																																																										
1	2012	Yukon	Body	Rear Heated Seat Module																																																										
1	2012	Yukon	Body	Rear HVAC/RSA																																																										
1	2012	Yukon	Body	Right Side Object Detection Module																																																										
1	2012	Yukon	Body	Supplemental Inflatable Restraint																																																										
1	2012	Yukon	Body	Theft Deterrent Module																										V	V	V	V																													
1	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																										
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2012	Yukon Hybrid	Body	Body Control Module																																																										
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2012	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2012	Yukon Hybrid	Body	Heated Seat Module																																																										
1	2012	Yukon Hybrid	Body	HVAC Control Module																																																										
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
1	2012	Yukon Hybrid	Body	Lift Gate Module																																																										
1	2012	Yukon Hybrid	Body	Park Assist Module																																																										
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2012	Yukon Hybrid	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2012	Yukon Hybrid	Body	Radio																																																										
1	2012	Yukon Hybrid	Body	Navigation Radio																																																										
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																											
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																											
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon XL	Body	Amplifier (Bose)																																																											
1	2012	Yukon XL	Body	Assist Step Controller																																																											
1	2012	Yukon XL	Body	Body Control Module																																																											
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																											
1	2012	Yukon XL	Body	Digital Radio Receiver																																																											
1	2012	Yukon XL	Body	Driver Door Switch																																																											
1	2012	Yukon XL	Body	HVAC Control Module Auto																																																											
1	2012	Yukon XL	Body	HVAC Control Module Manual																																																											
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																											
1	2012	Yukon XL	Body	Left Side Object Detection Module																																																											
1	2012	Yukon XL	Body	Lift Gate Module																																																											
1	2012	Yukon XL	Body	Memory Seat Module																																																											
1	2012	Yukon XL	Body	Park Assist Module																																																											
1	2012	Yukon XL	Body	Passenger Door Switch																																																											
1	2012	Yukon XL	Body	Passenger Presence System																																																											
1	2012	Yukon XL	Body	Radio																																																											
1	2012	Yukon XL	Body	Navigation Radio																																																											
1	2012	Yukon XL	Body	Rear Heated Seat Module																																																											
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																											
1	2012	Yukon XL	Body	Right Side Object Detection Module																																																											
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
1	2012	Yukon XL	Body	Theft Deterrent Module																										V	V	V	V																													
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module										V																																															
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																										
1	2013	Sierra	Chassis	Electronic Suspension Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Body	Amplifier (Bose)																																																										
1	2013	Sierra	Body	Body Control Module																																																										
1	2013	Sierra	Body	Body Control Module (aux.)																																																										
1	2013	Sierra	Body	Digital Radio Receiver																																																										
1	2013	Sierra	Body	Driver Door Switch																																																										
1	2013	Sierra	Body	HVAC Control Module Auto																																																										
1	2013	Sierra	Body	HVAC Control Module Manual																																																										
1	2013	Sierra	Body	Instrument Panel Cluster																																																										
1	2013	Sierra	Body	Memory Seat Module																																																										
1	2013	Sierra	Body	Park Assist Module																																																										
1	2013	Sierra	Body	Passenger Door Switch																																																										
1	2013	Sierra	Body	Passenger Presence System																																																										
1	2013	Sierra	Body	Radio																																																										
1	2013	Sierra	Body	Navigation Radio																																																										
1	2013	Sierra	Body	Rear Heated Seat Module																																																										
1	2013	Sierra	Body	Rear HVAC/RSA																																																										
1	2013	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2013	Sierra	Body	Theft Deterrent Module																										V	V	V	V																													
1	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																										
1	2013	Sierra Hybrid	Body	Body Control Module																																																										
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2013	Sierra Hybrid	Body	Driver Door Switch																																																										
1	2013	Sierra Hybrid	Body	Heated Seat Module																																																										
1	2013	Sierra Hybrid	Body	HVAC Control Module																																																										
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2013	Sierra Hybrid	Body	Park Assist Module																																																										
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																																										
1	2013	Sierra Hybrid	Body	Passenger Presence System																																																										
1	2013	Sierra Hybrid	Body	Radio																																																										
1	2013	Sierra Hybrid	Body	Navigation Radio																																																										
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2013	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2013	Yukon	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon	Body	Amplifier (Bose)																																																										
1	2013	Yukon	Body	Assist Step Controller																																																										
1	2013	Yukon	Body	Body Control Module																																																										
1	2013	Yukon	Body	Body Control Module (aux.)																																																										
1	2013	Yukon	Body	Digital Radio Receiver																																																										
1	2013	Yukon	Body	Driver Door Switch																																																										
1	2013	Yukon	Body	HVAC Control Module Auto																																																										
1	2013	Yukon	Body	HVAC Control Module Manual																																																										
1	2013	Yukon	Body	Instrument Panel Cluster																																																										
1	2013	Yukon	Body	Left Side Object Detection Module																																																										
1	2013	Yukon	Body	Lift Gate Module																																																										
1	2013	Yukon	Body	Memory Seat Module																																																										
1	2013	Yukon	Body	Park Assist Module																																																										
1	2013	Yukon	Body	Passenger Door Switch																																																										
1	2013	Yukon	Body	Passenger Presence System																																																										
1	2013	Yukon	Body	Radio																																																										
1	2013	Yukon	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2013	Yukon	Body	Rear Heated Seat Module																																																										
1	2013	Yukon	Body	Rear HVAC/RSA																																																										
1	2013	Yukon	Body	Right Side Object Detection Module																																																										
1	2013	Yukon	Body	Supplemental Inflatable Restraint																																																										
1	2013	Yukon	Body	Theft Deterrent Module																									V	V	V	V																														
1	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																										
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																V									
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2013	Yukon Hybrid	Body	Body Control Module																																																										
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2013	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2013	Yukon Hybrid	Body	Heated Seat Module																																																										
1	2013	Yukon Hybrid	Body	HVAC Control Module																																																										
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
1	2013	Yukon Hybrid	Body	Lift Gate Module																																																										
1	2013	Yukon Hybrid	Body	Park Assist Module																																																										
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2013	Yukon Hybrid	Body	Passenger Presence System																																																										
1	2013	Yukon Hybrid	Body	Radio																																																										
1	2013	Yukon Hybrid	Body	Navigation Radio																																																										
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																									V	V	V	V																														
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon XL	Body	Amplifier (Bose)																																																										
1	2013	Yukon XL	Body	Assist Step Controller																																																										
1	2013	Yukon XL	Body	Body Control Module																																																										
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2013	Yukon XL	Body	Digital Radio Receiver																																																										
1	2013	Yukon XL	Body	Driver Door Switch																																																										
1	2013	Yukon XL	Body	HVAC Control Module Auto																																																										
1	2013	Yukon XL	Body	HVAC Control Module Manual																																																										
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																										
1	2013	Yukon XL	Body	Left Side Object Detection Module																																																										
1	2013	Yukon XL	Body	Lift Gate Module																																																										
1	2013	Yukon XL	Body	Memory Seat Module																																																										
1	2013	Yukon XL	Body	Park Assist Module																																																										
1	2013	Yukon XL	Body	Passenger Door Switch																																																										
1	2013	Yukon XL	Body	Passenger Presence System																																																										
1	2013	Yukon XL	Body	Radio																																																										
1	2013	Yukon XL	Body	Navigation Radio																																																										
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																										
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																										
1	2013	Yukon XL	Body	Right Side Object Detection Module																																																										
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
1	2013	Yukon XL	Body	Theft Deterrent Module																										V	V	V	V																													
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																									
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																									
1	2014	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2014	Sierra	Chassis	Parking Brake Control Module																																																										
1	2014	Sierra	Chassis	Power Steering Control Module																																																										
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2014	Sierra	Body	Body Control Module																																																										
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Sierra	Body	Passenger Presence Module																																																										
1	2014	Sierra	Body	Instrument Cluster																																																										
1	2014	Sierra	Body	Radio Control																																																										
1	2014	Sierra	Body	HVAC Control																																																										
1	2014	Sierra	Body	Radio																																																										
1	2014	Sierra	Body	Amplifier																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2014	Sierra	Body	Media Disc Player																																																									
1	2014	Sierra	Body	Human Machine Interface Control Module																																																										
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2014	Sierra	Body	Parking Assist Control Module																																																										
1	2014	Sierra	Body	Frontview Camera Module																																																										
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																V	V																										
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Suspension Control Module																																																										
1	2014	Sierra HD	Body	Body Control Module																																																										
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Sierra HD	Body	Instrument Cluster																																																										
1	2014	Sierra HD	Body	Base Radio																																																										
1	2014	Sierra HD	Body	Navigation Radio																																																										
1	2014	Sierra HD	Body	Uplevel Radio																																																										
1	2014	Sierra HD	Body	Amplifier																																																										
1	2014	Sierra HD	Body	Rear Audio Control Module																																																										
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																										
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																										
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Sierra HD	Body	Seat Memory Control Module	V	V	V																																																								
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																										
1	2014	Sierra HD	Body	Parking Assist Control Module																																																										
1	2014	Sierra HD	Body	Theft Deterrent Module				V	V																																																					
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																										
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																							
1	2014	Yukon	Chassis	Electronic Brake Control Module																																																								
1	2014	Yukon	Chassis	Parking Brake Control Module																																																								
1	2014	Yukon	Chassis	Suspension Control Module																																																								
1	2014	Yukon	Body	Body Control Module																																																								
1	2014	Yukon	Body	Auxiliary Body Control Module																																																								
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2014	Yukon	Body	Passenger Presence Module																																																								
1	2014	Yukon	Body	Instrument Cluster																																																								
1	2014	Yukon	Body	Base Radio																																																								
1	2014	Yukon	Body	Navigation Radio																																																								
1	2014	Yukon	Body	Uplevel Radio																																																								
1	2014	Yukon	Body	Amplifier																																																								
1	2014	Yukon	Body	Rear Audio Control Module																																																								
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																																								
1	2014	Yukon	Body	Personal Audio Link Control Module																																																								
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																								
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																								
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																								
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																								
1	2014	Yukon	Body	Liftgate Control Module																																												V													
1	2014	Yukon	Body	Seat Memory Control Module	V	V	V																																																						
1	2014	Yukon	Body	Rear Seat Heating Control Module																																																								
1	2014	Yukon	Body	Assist Step Control Module																																																								
1	2014	Yukon	Body	Right Side Object Detection Control Module																																																								
1	2014	Yukon	Body	Left Side Object Detection Control Module																																																								
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																																								
1	2014	Yukon	Body	Parking Assist Control Module																																																								
1	2014	Yukon	Body	Theft Deterrent Module				V	V																																																			
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																								
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																								
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																								
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																								
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																								
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																								
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																								
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																								
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																																								
1	2014	Yukon XL	Chassis	Suspension Control Module																																																								
1	2014	Yukon XL	Body	Body Control Module																																																								
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																																								
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2014	Yukon XL	Body	Passenger Presence Module																																																								
1	2014	Yukon XL	Body	Instrument Cluster																																																								
1	2014	Yukon XL	Body	Base Radio																																																								
1	2014	Yukon XL	Body	Navigation Radio																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2014	Yukon XL	Body	Uplevel Radio																																																										
1	2014	Yukon XL	Body	Amplifier																																																										
1	2014	Yukon XL	Body	Rear Audio Control Module																																																										
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																										
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																																										
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Yukon XL	Body	Liftgate Control Module																																																										
1	2014	Yukon XL	Body	Seat Memory Control Module	V	V	V																																									V														
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																										
1	2014	Yukon XL	Body	Assist Step Control Module																																																										
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																										
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																										
1	2014	Yukon XL	Body	Parking Assist Control Module																																																										
1	2014	Yukon XL	Body	Theft Deterrent Module				V	V																																																					
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																V	V																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																										
1	2015	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Sierra	Chassis	Power Steering Control Module																																																										
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Sierra	Chassis	Suspension Control Module																																																										
1	2015	Sierra	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Sierra	Body	Passenger Presence Module																																																										
1	2015	Sierra	Body	Instrument Cluster																																																										
1	2015	Sierra	Body	Radio Controls																																																										
1	2015	Sierra	Body	HVAC Controls																																																										
1	2015	Sierra	Body	Radio																																																										
1	2015	Sierra	Body	Amplifier																																																										
1	2015	Sierra	Body	Media Disc Player																																																										
1	2015	Sierra	Body	Human Machine Interface Control Module																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2015	Sierra	Body	Parking Assist Control Module																																																										
1	2015	Sierra	Body	Frontview Camera Module																																																										
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																										
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																										
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																										
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																										
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																										
1	2015	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Yukon	Chassis	Parking Brake Control Module																																																										
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	Yukon	Chassis	Power Steering Control Module																																																										
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Yukon	Chassis	Suspension Control Module																																																										
1	2015	Yukon	Body	Body Control Module																																																										
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Yukon	Body	Passenger Presence Module																																																										
1	2015	Yukon	Body	Instrument Cluster																																																										
1	2015	Yukon	Body	Radio Controls																																																										
1	2015	Yukon	Body	HVAC Controls																																																										
1	2015	Yukon	Body	Radio																																																										
1	2015	Yukon	Body	Amplifier																																																										
1	2015	Yukon	Body	Media Disc Player																																																										
1	2015	Yukon	Body	Human Machine Interface Control Module																																																										
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2015	Yukon	Body	HVAC Control Module																																																								
1	2015	Yukon	Body	Liftgate Control Module																																						V	V	V	V	V	V													
1	2015	Yukon	Body	Keyless Entry Control Module																																																								
1	2015	Yukon	Body	Assist Step Control Module																																																								
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																								
1	2015	Yukon	Body	Parking Assist Control Module																																																								
1	2015	Yukon	Body	Frontview Camera Module																																																								
1	2015	Yukon	Body	Steering Column Lock Control Module																																																								
1	2015	Yukon	Body	Battery Energy Control Module																																																								
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																								
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																								
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																								
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																							
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																							
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																							
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																								
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																								
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																								
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																								
1	2015	Yukon XL	Chassis	Power Steering Control Module																																																								
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2015	Yukon XL	Chassis	Suspension Control Module																																																								
1	2015	Yukon XL	Body	Body Control Module																																																								
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2015	Yukon XL	Body	Passenger Presence Module																																																								
1	2015	Yukon XL	Body	Instrument Cluster																																																								
1	2015	Yukon XL	Body	Radio Controls																																																								
1	2015	Yukon XL	Body	HVAC Controls																																																								
1	2015	Yukon XL	Body	Radio																																																								
1	2015	Yukon XL	Body	Amplifier																																																								
1	2015	Yukon XL	Body	Media Disc Player																																																								
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																								
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																								
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																								
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																								
1	2015	Yukon XL	Body	HVAC Control Module																																																								
1	2015	Yukon XL	Body	Liftgate Control Module																																						V	V	V	V	V	V													
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																								
1	2015	Yukon XL	Body	Assist Step Control Module																																																								
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																								
1	2015	Yukon XL	Body	Parking Assist Control Module																																																								
1	2015	Yukon XL	Body	Frontview Camera Module																																																								
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																								
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																												V														
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																											V			V	V		V				V		
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																									
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																V	V																									
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																									
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																									
1	2016	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Sierra	Chassis	Parking Brake Control Module																																																										
1	2016	Sierra	Chassis	Power Steering Control Module																																																										
1	2016	Sierra	Chassis	Power Steering Control Module																																																										
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Sierra	Chassis	Suspension Control Module																																																										
1	2016	Sierra	Body	Body Control Module																																																										
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Sierra	Body	Passenger Presence Module																																																										
1	2016	Sierra	Body	Instrument Cluster																																																										
1	2016	Sierra	Body	Radio Controls																																																										
1	2016	Sierra	Body	HVAC Controls																																																										
1	2016	Sierra	Body	Radio (IO3)																																																										
1	2016	Sierra	Body	Radio (IOB)																																																										
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
1	2016	Sierra	Body	Amplifier																																																										
1	2016	Sierra	Body	Media Disc Player																																																										
1	2016	Sierra	Body	Human Machine Interface Control Module																																																										
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																										
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																										
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																										
1	2016	Sierra	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2016	Sierra	Body	Frontview Camera Module																																																									
1	2016	Sierra	Body	Frontview Camera Module																																																									
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																								
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																								
1	2016	Yukon	Chassis	Electronic Brake Control Module																																																									
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																									
1	2016	Yukon	Chassis	Parking Brake Control Module																																																									
1	2016	Yukon	Chassis	Power Steering Control Module																																																									
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2016	Yukon	Chassis	Suspension Control Module																																																									
1	2016	Yukon	Body	Body Control Module																																																									
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2016	Yukon	Body	Passenger Presence Module																																																									
1	2016	Yukon	Body	Instrument Cluster																																																									
1	2016	Yukon	Body	Radio Controls																																																									
1	2016	Yukon	Body	HVAC Controls																																																									
1	2016	Yukon	Body	Radio																																																									
1	2016	Yukon	Body	Amplifier																																																									
1	2016	Yukon	Body	Media Disc Player																																																									
1	2016	Yukon	Body	Human Machine Interface Control Module																																																									
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																									
1	2016	Yukon	Body	HVAC Control Module																																																									
1	2016	Yukon	Body	Liftgate Control Module																																					V	V	V	V	V	V															
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																									
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																									
1	2016	Yukon	Body	Keyless Entry Control Module																																																									
1	2016	Yukon	Body	Assist Step Control Module																																																									
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																									
1	2016	Yukon	Body	Parking Assist Control Module																																																									
1	2016	Yukon	Body	Frontview Camera Module																																																									
1	2016	Yukon	Body	Steering Column Lock Control Module																																																									
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																								
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																								
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																									
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																									
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																									
1	2016	Yukon XL	Chassis	Power Steering Control Module																																																									
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2016	Yukon XL	Chassis	Suspension Control Module																																																									
1	2016	Yukon XL	Body	Body Control Module																																																									
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
1	2016	Yukon XL	Body	Passenger Presence Module																																																									
1	2016	Yukon XL	Body	Instrument Cluster																																																									
1	2016	Yukon XL	Body	Radio Controls																																																									
1	2016	Yukon XL	Body	HVAC Controls																																																									
1	2016	Yukon XL	Body	Radio																																																									
1	2016	Yukon XL	Body	Amplifier																																																									
1	2016	Yukon XL	Body	Media Disc Player																																																									
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																									
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																									
1	2016	Yukon XL	Body	HVAC Control Module																																																									
1	2016	Yukon XL	Body	Liftgate Control Module																																						V	V	V	V	V	V													
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																									
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																									
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																									
1	2016	Yukon XL	Body	Assist Step Control Module																																																									
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																									
1	2016	Yukon XL	Body	Parking Assist Control Module																																																									
1	2016	Yukon XL	Body	Frontview Camera Module																																																									
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																									
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																V																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																V																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																V																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																V																										
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																V																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																V																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																									
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																V																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module										V																																															
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																									
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																									
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																									
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																V																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
2	2011	Sierra	Chassis	Electronic Suspension Control																																																										
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																										
2	2011	Sierra	Body	Amplifier (Bose)																																																										
2	2011	Sierra	Body	Body Control Module																																																										
2	2011	Sierra	Body	Body Control Module (aux.)																																																										
2	2011	Sierra	Body	Digital Radio Receiver																																																										
2	2011	Sierra	Body	Driver Door Switch																																																										
2	2011	Sierra	Body	HVAC Control Module Auto																																																										
2	2011	Sierra	Body	HVAC Control Module Manual																																																										
2	2011	Sierra	Body	Instrument Panel Cluster																																																										
2	2011	Sierra	Body	Memory Seat Module																																																										
2	2011	Sierra	Body	Park Assist Module																																																										
2	2011	Sierra	Body	Passenger Door Switch																																																										
2	2011	Sierra	Body	Passenger Presence System																																																										
2	2011	Sierra	Body	Radio																																																										
2	2011	Sierra	Body	Rear Heated Seat Module																																																										
2	2011	Sierra	Body	Rear HVAC/RSA																																																										
2	2011	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2011	Sierra	Body	Theft Deterrent Module																										V	V	V	V																													
2	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																	V								
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																V																										
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2011	Sierra Hybrid	Body	Body Control Module																																																										
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2011	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2011	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2011	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2011	Sierra Hybrid	Body	Park Assist Module																																																										
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2011	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2011	Sierra Hybrid	Body	Radio																																																										
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																									V	V	V	V																														
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																V																											
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																V																											
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2011	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2011	Yukon	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																										
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon	Body	Amplifier (Bose)																																																										
2	2011	Yukon	Body	Assist Step Controller																																																										
2	2011	Yukon	Body	Body Control Module																																																										
2	2011	Yukon	Body	Body Control Module (aux.)																																																										
2	2011	Yukon	Body	Digital Radio Receiver																																																										
2	2011	Yukon	Body	Driver Door Switch																																																										
2	2011	Yukon	Body	HVAC Control Module Auto																																																										
2	2011	Yukon	Body	HVAC Control Module Manual																																																										
2	2011	Yukon	Body	Instrument Panel Cluster																																																										
2	2011	Yukon	Body	Left Side Object Detection Module																																																										
2	2011	Yukon	Body	Lift Gate Module																																																										
2	2011	Yukon	Body	Memory Seat Module																																																										
2	2011	Yukon	Body	Park Assist Module																																																										
2	2011	Yukon	Body	Passenger Door Switch																																																										
2	2011	Yukon	Body	Passenger Presence System																																																										
2	2011	Yukon	Body	Radio																																																									
2	2011	Yukon	Body	Rear Heated Seat Module																																																										
2	2011	Yukon	Body	Rear HVAC/RSA																																																										
2	2011	Yukon	Body	Right Side Object Detection Module																																																										
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2011	Yukon	Body	Theft Deterrent Module																									V	V	V	V																														
2	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																V																											
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																									
2	2011	Yukon Hybrid	Body	Body Control Module																																																									
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																									
2	2011	Yukon Hybrid	Body	Driver Door Switch																																																									
2	2011	Yukon Hybrid	Body	Heated Seat Module																																																									
2	2011	Yukon Hybrid	Body	HVAC Control Module																																																									
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																									
2	2011	Yukon Hybrid	Body	Lift Gate Module																																																									
2	2011	Yukon Hybrid	Body	Park Assist Module																																																									
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																																									
2	2011	Yukon Hybrid	Body	Passenger Presence System																																																									
2	2011	Yukon Hybrid	Body	Radio																																																									
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																										V	V	V	V																												
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																	V																								
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																	V																								
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																	V																								
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																	V																								
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																	V																								
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																									
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																									
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																									
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
2	2011	Yukon XL	Body	Amplifier (Bose)																																																									
2	2011	Yukon XL	Body	Assist Step Controller																																																									
2	2011	Yukon XL	Body	Body Control Module																																																									
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																									
2	2011	Yukon XL	Body	Digital Radio Receiver																																																									
2	2011	Yukon XL	Body	Driver Door Switch																																																									
2	2011	Yukon XL	Body	HVAC Control Module Auto																																																									
2	2011	Yukon XL	Body	HVAC Control Module Manual																																																									
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																									
2	2011	Yukon XL	Body	Left Side Object Detection Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2011	Yukon XL	Body	Lift Gate Module																																																									
2	2011	Yukon XL	Body	Memory Seat Module																																																									
2	2011	Yukon XL	Body	Park Assist Module																																																									
2	2011	Yukon XL	Body	Passenger Door Switch																																																									
2	2011	Yukon XL	Body	Passenger Presence System																																																									
2	2011	Yukon XL	Body	Radio																																																									
2	2011	Yukon XL	Body	Rear Heated Seat Module																																																									
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																									
2	2011	Yukon XL	Body	Right Side Object Detection Module																																																									
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
2	2011	Yukon XL	Body	Theft Deterrent Module																										V	V	V	V																												
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																	V																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																	V																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																	V																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																	V																								
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																	V																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																	V																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																									
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																	V																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module										V																																															
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																									
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																									
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																									
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																	V																								
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																									
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																									
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
2	2012	Sierra	Chassis	Electronic Suspension Control																																																									
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																									
2	2012	Sierra	Body	Amplifier (Bose)																																																									
2	2012	Sierra	Body	Body Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2012	Sierra	Body	Body Control Module (aux.)																																																										
2	2012	Sierra	Body	Digital Radio Receiver																																																										
2	2012	Sierra	Body	Driver Door Switch																																																										
2	2012	Sierra	Body	HVAC Control Module Auto																																																										
2	2012	Sierra	Body	HVAC Control Module Manual																																																										
2	2012	Sierra	Body	Instrument Panel Cluster																																																										
2	2012	Sierra	Body	Memory Seat Module																																																										
2	2012	Sierra	Body	Park Assist Module																																																										
2	2012	Sierra	Body	Passenger Door Switch																																																										
2	2012	Sierra	Body	Passenger Presence System																																																										
2	2012	Sierra	Body	Radio																																																										
2	2012	Sierra	Body	Navigation Radio																																																										
2	2012	Sierra	Body	Rear Heated Seat Module																																																										
2	2012	Sierra	Body	Rear HVAC/RSA																																																										
2	2012	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra	Body	Theft Deterrent Module																										V	V	V	V																													
2	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																	V								
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																	V																									
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Sierra Hybrid	Body	Body Control Module																																																										
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2012	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2012	Sierra Hybrid	Body	Park Assist Module																																																										
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2012	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2012	Sierra Hybrid	Body	Radio																																																										
2	2012	Sierra Hybrid	Body	Navigation Radio																																																										
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																V																							
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																V																							
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																							
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																							
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																							
2	2012	Yukon	Chassis	Electronic Brake Control Module																																																							
2	2012	Yukon	Chassis	Electronic Suspension Control																																																							
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																							
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																							
2	2012	Yukon	Body	Amplifier (Bose)																																																							
2	2012	Yukon	Body	Assist Step Controller																																																							
2	2012	Yukon	Body	Body Control Module																																																							
2	2012	Yukon	Body	Body Control Module (aux.)																																																							
2	2012	Yukon	Body	Digital Radio Receiver																																																							
2	2012	Yukon	Body	Driver Door Switch																																																							
2	2012	Yukon	Body	HVAC Control Module Auto																																																							
2	2012	Yukon	Body	HVAC Control Module Manual																																																							
2	2012	Yukon	Body	Instrument Panel Cluster																																																							
2	2012	Yukon	Body	Left Side Object Detection Module																																																							
2	2012	Yukon	Body	Lift Gate Module																																																							
2	2012	Yukon	Body	Memory Seat Module																																																							
2	2012	Yukon	Body	Park Assist Module																																																							
2	2012	Yukon	Body	Passenger Door Switch																																																							
2	2012	Yukon	Body	Passenger Presence System																																																							
2	2012	Yukon	Body	Radio																																																							
2	2012	Yukon	Body	Navigation Radio																																																							
2	2012	Yukon	Body	Rear Heated Seat Module																																																							
2	2012	Yukon	Body	Rear HVAC/RSA																																																							
2	2012	Yukon	Body	Right Side Object Detection Module																																																							
2	2012	Yukon	Body	Supplemental Inflatable Restraint																																																							
2	2012	Yukon	Body	Theft Deterrent Module																										V	V	V	V																										
2	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																							
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																							
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																							
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																							
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																							
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																							
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																							
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																							
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																V																							
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																							
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																							
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																							
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																							
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																							
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																							
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																							
2	2012	Yukon Hybrid	Body	Body Control Module																																																							
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																							
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																							
2	2012	Yukon Hybrid	Body	Driver Door Switch																																																							

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2012	Yukon Hybrid	Body	Heated Seat Module																																																										
2	2012	Yukon Hybrid	Body	HVAC Control Module																																																										
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
2	2012	Yukon Hybrid	Body	Lift Gate Module																																																										
2	2012	Yukon Hybrid	Body	Park Assist Module																																																										
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																																										
2	2012	Yukon Hybrid	Body	Passenger Presence System																																																										
2	2012	Yukon Hybrid	Body	Radio																																																										
2	2012	Yukon Hybrid	Body	Navigation Radio																																																										
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																	V																										
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																	V																										
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																	V																										
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																	V																										
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																	V																										
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																										
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																										
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Yukon XL	Body	Amplifier (Bose)																																																										
2	2012	Yukon XL	Body	Assist Step Controller																																																										
2	2012	Yukon XL	Body	Body Control Module																																																										
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																										
2	2012	Yukon XL	Body	Digital Radio Receiver																																																										
2	2012	Yukon XL	Body	Driver Door Switch																																																										
2	2012	Yukon XL	Body	HVAC Control Module Auto																																																										
2	2012	Yukon XL	Body	HVAC Control Module Manual																																																										
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																										
2	2012	Yukon XL	Body	Left Side Object Detection Module																																																										
2	2012	Yukon XL	Body	Lift Gate Module																																																										
2	2012	Yukon XL	Body	Memory Seat Module																																																										
2	2012	Yukon XL	Body	Park Assist Module																																																										
2	2012	Yukon XL	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2012	Yukon XL	Body	Passenger Presence System																																																										
2	2012	Yukon XL	Body	Radio																																																										
2	2012	Yukon XL	Body	Navigation Radio																																																										
2	2012	Yukon XL	Body	Rear Heated Seat Module																																																										
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																										
2	2012	Yukon XL	Body	Right Side Object Detection Module																																																										
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
2	2012	Yukon XL	Body	Theft Deterrent Module																										V	V	V	V																													
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																V																												
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																V																												
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																V																												
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																V																												
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																V																												
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																											
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																V																												
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																V																												
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module										V																																																	
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																V																												
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																											
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																											
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																											
2	2013	Sierra	Chassis	Electronic Suspension Control																																																											
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
2	2013	Sierra	Body	Amplifier (Bose)																																																											
2	2013	Sierra	Body	Body Control Module																																																											
2	2013	Sierra	Body	Body Control Module (aux.)																																																											
2	2013	Sierra	Body	Digital Radio Receiver																																																											
2	2013	Sierra	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2013	Sierra	Body	HVAC Control Module Auto																																																										
2	2013	Sierra	Body	HVAC Control Module Manual																																																										
2	2013	Sierra	Body	Instrument Panel Cluster																																																										
2	2013	Sierra	Body	Memory Seat Module																																																										
2	2013	Sierra	Body	Park Assist Module																																																										
2	2013	Sierra	Body	Passenger Door Switch																																																										
2	2013	Sierra	Body	Passenger Presence System																																																										
2	2013	Sierra	Body	Radio																																																										
2	2013	Sierra	Body	Navigation Radio																																																										
2	2013	Sierra	Body	Rear Heated Seat Module																																																										
2	2013	Sierra	Body	Rear HVAC/RSA																																																										
2	2013	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2013	Sierra	Body	Theft Deterrent Module																										V	V	V	V																													
2	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																V									
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																	V																									
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Sierra Hybrid	Body	Body Control Module																																																										
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2013	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2013	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2013	Sierra Hybrid	Body	Park Assist Module																																																										
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2013	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2013	Sierra Hybrid	Body	Radio																																																										
2	2013	Sierra Hybrid	Body	Navigation Radio																																																										
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																										V	V	V	V																													
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																	V																									
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																	V																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2013	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Body	Amplifier (Bose)																																																										
2	2013	Yukon	Body	Assist Step Controller																																																										
2	2013	Yukon	Body	Body Control Module																																																										
2	2013	Yukon	Body	Body Control Module (aux.)																																																										
2	2013	Yukon	Body	Digital Radio Receiver																																																										
2	2013	Yukon	Body	Driver Door Switch																																																										
2	2013	Yukon	Body	HVAC Control Module Auto																																																										
2	2013	Yukon	Body	HVAC Control Module Manual																																																										
2	2013	Yukon	Body	Instrument Panel Cluster																																																										
2	2013	Yukon	Body	Left Side Object Detection Module																																																										
2	2013	Yukon	Body	Lift Gate Module																																																										
2	2013	Yukon	Body	Memory Seat Module																																																										
2	2013	Yukon	Body	Park Assist Module																																																										
2	2013	Yukon	Body	Passenger Door Switch																																																										
2	2013	Yukon	Body	Passenger Presence System																																																										
2	2013	Yukon	Body	Radio																																																										
2	2013	Yukon	Body	Navigation Radio																																																										
2	2013	Yukon	Body	Rear Heated Seat Module																																																										
2	2013	Yukon	Body	Rear HVAC/RSA																																																										
2	2013	Yukon	Body	Right Side Object Detection Module																																																										
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2013	Yukon	Body	Theft Deterrent Module																										V	V	V	V																													
2	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																															V											
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																	V																									
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2013	Yukon Hybrid	Body	Body Control Module																																																										
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Yukon Hybrid	Body	Driver Door Switch																																																										
2	2013	Yukon Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2013	Yukon Hybrid	Body	HVAC Control Module																																																									
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																									
2	2013	Yukon Hybrid	Body	Lift Gate Module																																																									
2	2013	Yukon Hybrid	Body	Park Assist Module																																																									
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																																									
2	2013	Yukon Hybrid	Body	Passenger Presence System																																																									
2	2013	Yukon Hybrid	Body	Radio																																																									
2	2013	Yukon Hybrid	Body	Navigation Radio																																																									
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																										V	V	V	V																												
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																	V																								
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																	V																								
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																	V																								
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																	V																								
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																	V																								
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																									
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																									
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Yukon XL	Body	Amplifier (Bose)																																																									
2	2013	Yukon XL	Body	Assist Step Controller																																																									
2	2013	Yukon XL	Body	Body Control Module																																																									
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																									
2	2013	Yukon XL	Body	Digital Radio Receiver																																																									
2	2013	Yukon XL	Body	Driver Door Switch																																																									
2	2013	Yukon XL	Body	HVAC Control Module Auto																																																									
2	2013	Yukon XL	Body	HVAC Control Module Manual																																																									
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																									
2	2013	Yukon XL	Body	Left Side Object Detection Module																																																									
2	2013	Yukon XL	Body	Lift Gate Module																																																									
2	2013	Yukon XL	Body	Memory Seat Module																																																									
2	2013	Yukon XL	Body	Park Assist Module																																																									
2	2013	Yukon XL	Body	Passenger Door Switch																																																									
2	2013	Yukon XL	Body	Passenger Presence System																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2013	Yukon XL	Body	Radio																																																									
2	2013	Yukon XL	Body	Navigation Radio																																																									
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																									
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																									
2	2013	Yukon XL	Body	Right Side Object Detection Module																																																									
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
2	2013	Yukon XL	Body	Theft Deterrent Module																										V	V	V	V																												
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																									
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																								
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																								
2	2014	Sierra	Chassis	Electronic Brake Control Module																																																									
2	2014	Sierra	Chassis	Parking Brake Control Module																																																									
2	2014	Sierra	Chassis	Power Steering Control Module																																																									
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2014	Sierra	Body	Body Control Module																																																									
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2014	Sierra	Body	Passenger Presence Module																																																									
2	2014	Sierra	Body	Instrument Cluster																																																									
2	2014	Sierra	Body	Radio Control																																																									
2	2014	Sierra	Body	HVAC Control																																																									
2	2014	Sierra	Body	Radio																																																									
2	2014	Sierra	Body	Amplifier																																																									
2	2014	Sierra	Body	Media Disc Player																																																									
2	2014	Sierra	Body	Human Machine Interface Control Module																																																									
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																									
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																									
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																									
2	2014	Sierra	Body	Parking Assist Control Module																																																									
2	2014	Sierra	Body	Frontview Camera Module																																																									
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																									
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																V	V																								
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																									
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																									
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2014	Sierra HD	Chassis	Suspension Control Module																																																											
2	2014	Sierra HD	Body	Body Control Module																																																											
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2014	Sierra HD	Body	Instrument Cluster																																																											
2	2014	Sierra HD	Body	Base Radio																																																											
2	2014	Sierra HD	Body	Navigation Radio																																																											
2	2014	Sierra HD	Body	Uplevel Radio																																																											
2	2014	Sierra HD	Body	Amplifier																																																											
2	2014	Sierra HD	Body	Rear Audio Control Module																																																											
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																											
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																											
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																											
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																											
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																											
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																											
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																											
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																											
2	2014	Sierra HD	Body	Seat Memory Control Module	V	V	V																																																									
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																											
2	2014	Sierra HD	Body	Parking Assist Control Module																																																											
2	2014	Sierra HD	Body	Theft Deterrent Module				V	V																																																						
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																											
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																											
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																											
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																											
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																										
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																											
2	2014	Yukon	Chassis	Parking Brake Control Module																																																											
2	2014	Yukon	Chassis	Suspension Control Module																																																											
2	2014	Yukon	Body	Body Control Module																																																											
2	2014	Yukon	Body	Auxiliary Body Control Module																																																											
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2014	Yukon	Body	Passenger Presence Module																																																											
2	2014	Yukon	Body	Instrument Cluster																																																											
2	2014	Yukon	Body	Base Radio																																																											
2	2014	Yukon	Body	Navigation Radio																																																											
2	2014	Yukon	Body	Uplevel Radio																																																											
2	2014	Yukon	Body	Amplifier																																																											
2	2014	Yukon	Body	Rear Audio Control Module																																																											
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																											
2	2014	Yukon	Body	Personal Audio Link Control Module																																																											
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																											
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																											
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Yukon	Body	Liftgate Control Module																																											V															
2	2014	Yukon	Body	Seat Memory Control Module	V	V	V																																																						
2	2014	Yukon	Body	Rear Seat Heating Control Module																																																										
2	2014	Yukon	Body	Assist Step Control Module																																																										
2	2014	Yukon	Body	Right Side Object Detection Control Module																																																										
2	2014	Yukon	Body	Left Side Object Detection Control Module																																																										
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																										
2	2014	Yukon	Body	Parking Assist Control Module																																																										
2	2014	Yukon	Body	Theft Deterrent Module				V	V																																																					
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																										
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																										
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																										
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																										
2	2014	Yukon XL	Chassis	Suspension Control Module																																																										
2	2014	Yukon XL	Body	Body Control Module																																																										
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																										
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Yukon XL	Body	Passenger Presence Module																																																										
2	2014	Yukon XL	Body	Instrument Cluster																																																										
2	2014	Yukon XL	Body	Base Radio																																																										
2	2014	Yukon XL	Body	Navigation Radio																																																										
2	2014	Yukon XL	Body	Uplevel Radio																																																										
2	2014	Yukon XL	Body	Amplifier																																																										
2	2014	Yukon XL	Body	Rear Audio Control Module																																																										
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																										
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																										
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																										
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Yukon XL	Body	Liftgate Control Module																																											V															
2	2014	Yukon XL	Body	Seat Memory Control Module	V	V	V																																																							
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																										
2	2014	Yukon XL	Body	Assist Step Control Module																																																										
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																										
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																										
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																										
2	2014	Yukon XL	Body	Parking Assist Control Module																																																										
2	2014	Yukon XL	Body	Theft Deterrent Module				V	V																																																					
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																V	V																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																										
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																										
2	2015	Sierra	Chassis	Electronic Brake Control Module																																																										
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Sierra	Chassis	Power Steering Control Module																																																										
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Sierra	Chassis	Suspension Control Module																																																										
2	2015	Sierra	Body	Body Control Module																																																										
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Sierra	Body	Passenger Presence Module																																																										
2	2015	Sierra	Body	Instrument Cluster																																																										
2	2015	Sierra	Body	Radio Controls																																																										
2	2015	Sierra	Body	HVAC Controls																																																										
2	2015	Sierra	Body	Radio																																																										
2	2015	Sierra	Body	Amplifier																																																										
2	2015	Sierra	Body	Media Disc Player																																																										
2	2015	Sierra	Body	Human Machine Interface Control Module																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2015	Sierra	Body	Parking Assist Control Module																																																										
2	2015	Sierra	Body	Frontview Camera Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																									
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																								
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																								
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																								
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																									
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																									
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																									
2	2015	Yukon	Chassis	Electronic Brake Control Module																																																									
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																									
2	2015	Yukon	Chassis	Parking Brake Control Module																																																									
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																									
2	2015	Yukon	Chassis	Power Steering Control Module																																																									
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2015	Yukon	Chassis	Suspension Control Module																																																									
2	2015	Yukon	Body	Body Control Module																																																									
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2015	Yukon	Body	Passenger Presence Module																																																									
2	2015	Yukon	Body	Instrument Cluster																																																									
2	2015	Yukon	Body	Radio Controls																																																									
2	2015	Yukon	Body	HVAC Controls																																																									
2	2015	Yukon	Body	Radio																																																									
2	2015	Yukon	Body	Amplifier																																																									
2	2015	Yukon	Body	Media Disc Player																																																									
2	2015	Yukon	Body	Human Machine Interface Control Module																																																									
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																									
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																									
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2015	Yukon	Body	HVAC Control Module																																																									
2	2015	Yukon	Body	Liftgate Control Module																																					V	V	V	V	V	V															
2	2015	Yukon	Body	Keyless Entry Control Module																																																									
2	2015	Yukon	Body	Assist Step Control Module																																																									
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																									
2	2015	Yukon	Body	Parking Assist Control Module																																																									
2	2015	Yukon	Body	Frontview Camera Module																																																									
2	2015	Yukon	Body	Steering Column Lock Control Module																																																									
2	2015	Yukon	Body	Battery Energy Control Module																																																									
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																									
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																V	V																								
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																								
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																								
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																									
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																									
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																									
2	2015	Yukon XL	Chassis	Power Steering Control Module																																																									
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2015	Yukon XL	Chassis	Suspension Control Module																																																									
2	2015	Yukon XL	Body	Body Control Module																																																									
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2015	Yukon XL	Body	Passenger Presence Module																																																									
2	2015	Yukon XL	Body	Instrument Cluster																																																									
2	2015	Yukon XL	Body	Radio Controls																																																									
2	2015	Yukon XL	Body	HVAC Controls																																																									
2	2015	Yukon XL	Body	Radio																																																									
2	2015	Yukon XL	Body	Amplifier																																																									
2	2015	Yukon XL	Body	Media Disc Player																																																									
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																									
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																									
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																									
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2015	Yukon XL	Body	HVAC Control Module																																																									
2	2015	Yukon XL	Body	Liftgate Control Module																																					V	V	V	V	V	V															
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																									
2	2015	Yukon XL	Body	Assist Step Control Module																																																									
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																									
2	2015	Yukon XL	Body	Parking Assist Control Module																																																									
2	2015	Yukon XL	Body	Frontview Camera Module																																																									
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																									
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																									
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																									
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																									
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																												V													
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																												V		V	V		V				V			
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																									
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																									
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																V	V																								
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																V	V																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																							
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																							
2	2016	Sierra	Chassis	Electronic Brake Control Module																																																								
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																							
2	2016	Sierra	Chassis	Parking Brake Control Module																																																							
2	2016	Sierra	Chassis	Power Steering Control Module																																																							
2	2016	Sierra	Chassis	Power Steering Control Module																																																							
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																							
2	2016	Sierra	Chassis	Suspension Control Module																																																							
2	2016	Sierra	Body	Body Control Module																																																							
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
2	2016	Sierra	Body	Passenger Presence Module																																																							
2	2016	Sierra	Body	Instrument Cluster																																																							
2	2016	Sierra	Body	Radio Controls																																																							
2	2016	Sierra	Body	HVAC Controls																																																							
2	2016	Sierra	Body	Radio (IO3)																																																							
2	2016	Sierra	Body	Radio (IOB)																																																							
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																							
2	2016	Sierra	Body	Amplifier																																																							
2	2016	Sierra	Body	Media Disc Player																																																							
2	2016	Sierra	Body	Human Machine Interface Control Module																																																							
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																							
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																							
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																							
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																							
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																							
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																							
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																							
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																							
2	2016	Sierra	Body	Parking Assist Control Module																																																							
2	2016	Sierra	Body	Frontview Camera Module																																																							
2	2016	Sierra	Body	Frontview Camera Module																																																							
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																							
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																							
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																							
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																							
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																							
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																V	V																							
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																V	V																							
2	2016	Yukon	Chassis	Electronic Brake Control Module																																																							
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																							
2	2016	Yukon	Chassis	Parking Brake Control Module																																																							
2	2016	Yukon	Chassis	Power Steering Control Module																																																							
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																							
2	2016	Yukon	Chassis	Suspension Control Module																																																							
2	2016	Yukon	Body	Body Control Module																																																							
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
2	2016	Yukon	Body	Passenger Presence Module																																																							
2	2016	Yukon	Body	Instrument Cluster																																																							
2	2016	Yukon	Body	Radio Controls																																																							
2	2016	Yukon	Body	HVAC Controls																																																							

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
2	2016	Yukon	Body	Radio																																																								
2	2016	Yukon	Body	Amplifier																																																								
2	2016	Yukon	Body	Media Disc Player																																																								
2	2016	Yukon	Body	Human Machine Interface Control Module																																																								
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																								
2	2016	Yukon	Body	HVAC Control Module																																																								
2	2016	Yukon	Body	Liftgate Control Module																																					V	V	V	V	V	V														
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																								
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																								
2	2016	Yukon	Body	Keyless Entry Control Module																																																								
2	2016	Yukon	Body	Assist Step Control Module																																																								
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																								
2	2016	Yukon	Body	Parking Assist Control Module																																																								
2	2016	Yukon	Body	Frontview Camera Module																																																								
2	2016	Yukon	Body	Steering Column Lock Control Module																																																								
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																															V	V																								
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																															V	V																								
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																								
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																								
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																								
2	2016	Yukon XL	Chassis	Power Steering Control Module																																																								
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																								
2	2016	Yukon XL	Chassis	Suspension Control Module																																																								
2	2016	Yukon XL	Body	Body Control Module																																																								
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
2	2016	Yukon XL	Body	Passenger Presence Module																																																								
2	2016	Yukon XL	Body	Instrument Cluster																																																								
2	2016	Yukon XL	Body	Radio Controls																																																								
2	2016	Yukon XL	Body	HVAC Controls																																																								
2	2016	Yukon XL	Body	Radio																																																								
2	2016	Yukon XL	Body	Amplifier																																																								
2	2016	Yukon XL	Body	Media Disc Player																																																								
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																								
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																								
2	2016	Yukon XL	Body	HVAC Control Module																																																								
2	2016	Yukon XL	Body	Liftgate Control Module																																					V	V	V	V	V	V														
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																								
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																								
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																								
2	2016	Yukon XL	Body	Assist Step Control Module																																																								
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																								
2	2016	Yukon XL	Body	Parking Assist Control Module																																																								
2	2016	Yukon XL	Body	Frontview Camera Module																																																								
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																								
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																							V																																	
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
5	2011	ALL	Chassis	Electronic Brake Control Module																																																										
5	2011	ALL	Body	Body Control Module																																																										
5	2011	ALL	Body	Digital Radio Receiver																																																										
5	2011	ALL	Body	Generator Battery Control Module																																																										
5	2011	ALL	Body	Instrument Panel Cluster																																																										
5	2011	ALL	Body	Passenger Presence System																																																										
5	2011	ALL	Body	Personal Audio Link Module																																																										
5	2011	ALL	Body	Base Radio																																																										
5	2011	ALL	Body	Uplevel Radio																																																										
5	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
5	2011	ALL	Body	Theft Deterrent Module																																																										
5	2011	ALL	Body	Vehicle Comm. Interface Module																																																										
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																				
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																				
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
5	2012	ALL	Chassis	Electronic Brake Control Module																																																										
5	2012	ALL	Body	Body Control Module																																																										
5	2012	ALL	Body	Digital Radio Receiver																																																										
5	2012	ALL	Body	Generator Battery Control Module																																																										
5	2012	ALL	Body	Instrument Panel Cluster																																																										
5	2012	ALL	Body	Passenger Presence System																																																										
5	2012	ALL	Body	Personal Audio Link Module																																																										
5	2012	ALL	Body	Base Radio																																																										
5	2012	ALL	Body	Uplevel Radio																																																										
5	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
5	2012	ALL	Body	Theft Deterrent Module																																																										
5	2012	ALL	Body	Vehicle Comm. Interface Module																																																										
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
5	2015	Canyon	Powertrain	Chassis Control Module																																																										
5	2015	Canyon	Powertrain	Transfer Case Control Module																																V	V																										
5	2015	Canyon	Chassis	Electronic Brake Control Module																																																										
5	2015	Canyon	Chassis	Power Steering Control Module																																																										
5	2015	Canyon	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
5	2015	Canyon	Body	Passenger Presence Module																																																									
5	2015	Canyon	Body	Radio																																																								
5	2015	Canyon	Body	Amplifier																																																								
5	2015	Canyon	Body	Human Machine Interface Control Module																																																								
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																																								
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																								
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																								
5	2015	Canyon	Body	Parking Assist Control Module																																																								
5	2015	Canyon	Body	Frontview Camera Module																																																								
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																								
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
5	2016	Canyon	Powertrain	Transfer Case Control Module																																V	V																								
5	2016	Canyon	Chassis	Electronic Brake Control Module																																																								
5	2016	Canyon	Chassis	Power Steering Control Module																																																								
5	2016	Canyon	Body	Body Control Module																																																								
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
5	2016	Canyon	Body	Passenger Presence Module																																																								
5	2016	Canyon	Body	Trailer Interface Control Module																																																								
5	2016	Canyon	Body	Radio																																																								
5	2016	Canyon	Body	Amplifier																																																								
5	2016	Canyon	Body	Human Machine Interface Control Module																																																								
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																																								
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																								
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																								
5	2016	Canyon	Body	Frontview Camera Module																																																								
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																		
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																		
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																								
6	2011	ALL	Chassis	Electronic Brake Control Module																																																								
6	2011	ALL	Body	Body Control Module																																																								
6	2011	ALL	Body	Digital Radio Receiver																																																								
6	2011	ALL	Body	Generator Battery Control Module																																																								
6	2011	ALL	Body	Instrument Panel Cluster																																																								
6	2011	ALL	Body	Passenger Presence System																																																								
6	2011	ALL	Body	Personal Audio Link Module																																																								
6	2011	ALL	Body	Base Radio																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
6	2011	ALL	Body	Uplevel Radio																																																									
6	2011	ALL	Body	Supplemental Inflatable Restraint																																																									
6	2011	ALL	Body	Theft Deterrent Module																																																									
6	2011	ALL	Body	Vehicle Comm. Interface Module																																																									
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																						V																																			
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																									
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																						V																																			
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																									
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																									
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																									
6	2012	ALL	Chassis	Electronic Brake Control Module																																																									
6	2012	ALL	Body	Body Control Module																																																									
6	2012	ALL	Body	Digital Radio Receiver																																																									
6	2012	ALL	Body	Generator Battery Control Module																																																									
6	2012	ALL	Body	Instrument Panel Cluster																																																									
6	2012	ALL	Body	Passenger Presence System																																																									
6	2012	ALL	Body	Personal Audio Link Module																																																									
6	2012	ALL	Body	Base Radio																																																									
6	2012	ALL	Body	Uplevel Radio																																																									
6	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
6	2012	ALL	Body	Theft Deterrent Module																																																									
6	2012	ALL	Body	Vehicle Comm. Interface Module																																																									
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																									
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																									
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																									
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
6	2015	Canyon	Powertrain	Chassis Control Module																																																									
6	2015	Canyon	Powertrain	Transfer Case Control Module																																V	V																								
6	2015	Canyon	Chassis	Electronic Brake Control Module																																																									
6	2015	Canyon	Chassis	Power Steering Control Module																																																									
6	2015	Canyon	Body	Body Control Module																																																									
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
6	2015	Canyon	Body	Passenger Presence Module																																																									
6	2015	Canyon	Body	Radio																																																									
6	2015	Canyon	Body	Amplifier																																																									
6	2015	Canyon	Body	Human Machine Interface Control Module																																																									
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																																									
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																									
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																									
6	2015	Canyon	Body	Parking Assist Control Module																																																									
6	2015	Canyon	Body	Frontview Camera Module																																																									
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
6	2016	Canyon	Powertrain	Transfer Case Control Module																																V	V																									
6	2016	Canyon	Chassis	Electronic Brake Control Module																																																										
6	2016	Canyon	Chassis	Power Steering Control Module																																																										
6	2016	Canyon	Body	Body Control Module																																																										
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
6	2016	Canyon	Body	Passenger Presence Module																																																										
6	2016	Canyon	Body	Trailer Interface Control Module																																																										
6	2016	Canyon	Body	Radio																																																										
6	2016	Canyon	Body	Amplifier																																																										
6	2016	Canyon	Body	Human Machine Interface Control Module																																																										
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																																										
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
6	2016	Canyon	Body	Frontview Camera Module																																																										
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2011	Express/Savana	Body	Body Control Module																																																										
7	2011	Express/Savana	Body	Digital Radio Receiver																																																										
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
7	2011	Express/Savana	Body	Passenger Presence System																																																										
7	2011	Express/Savana	Body	Radio																																																										
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
7	2011	Express/Savana	Body	Rollover Sensor																																																										
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
7	2011	Express/Savana	Body	Theft Deterrent Module																										V	V	V	V																												
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2011	Express Access/Savana Pro	Body	Body Control Module																																																										
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																										
7	2011	Express Access/Savana Pro	Body	Radio																																																										
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																										
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																														
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																															
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2012	Express/Savana	Body	Body Control Module																																																										
7	2012	Express/Savana	Body	Digital Radio Receiver																																																										
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																										
7	2012	Express/Savana	Body	Passenger Presence System																																																										
7	2012	Express/Savana	Body	Radio																																																										
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
7	2012	Express/Savana	Body	Rollover Sensor																																																										
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
7	2012	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																														
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																														
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
7	2012	Express Access/Savana Pro	Body	Body Control Module																																																								
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																								
7	2012	Express Access/Savana Pro	Body	Radio																																																								
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																									V	V	V	V																												
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																														
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
7	2013	Express/Savana	Body	Body Control Module																																																								
7	2013	Express/Savana	Body	Digital Radio Receiver																																																								
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
7	2013	Express/Savana	Body	Passenger Presence System																																																								
7	2013	Express/Savana	Body	Radio																																																								
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
7	2013	Express/Savana	Body	Rollover Sensor																																																								
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
7	2013	Express/Savana	Body	Theft Deterrent Module																									V	V	V	V																												
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																																
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
7	2013	Express Access/Savana Pro	Body	Body Control Module																																																											
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																											
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																											
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																											
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																											
7	2013	Express Access/Savana Pro	Body	Radio																																																											
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																											
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																										V	V	V	V																														
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																											
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																											
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																											
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																											
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																											
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																											
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																											
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
7	2014	Savana	Chassis	Electronic Brake Control Module																																																											
7	2014	Savana	Body	Body Control Module																																																											
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
7	2014	Savana	Body	Passenger Presence Module																																																											
7	2014	Savana	Body	Rollover Sensor Module																																																											
7	2014	Savana	Body	Instrument Cluster																																																											
7	2014	Savana	Body	Chime Alarm Control Module																																																											
7	2014	Savana	Body	Base Radio																																																											
7	2014	Savana	Body	Navigation Radio																																																											
7	2014	Savana	Body	Uplevel Radio																																																											
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																											
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
7	2014	Savana	Body	Auxiliary Heater Control Module																																																										
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2014	Savana	Body	Parking Assist Control Module																																																										
7	2014	Savana	Body	Theft Deterrent Module				V	V																																																					
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2015	Savana	Chassis	Electronic Brake Control Module																																																										
7	2015	Savana	Body	Body Control Module																																																										
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2015	Savana	Body	Rollover Sensor Module																																																										
7	2015	Savana	Body	Instrument Cluster																																																										
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
7	2015	Savana	Body	Auxiliary Heater Control Module																																																										
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2015	Savana	Body	Parking Assist Control Module																																																										
7	2015	Savana	Body	Theft Deterrent Module				V	V																																																					
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2016	Savana	Chassis	Electronic Brake Control Module																																																										
7	2016	Savana	Body	Body Control Module																																																										
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2016	Savana	Body	Instrument Cluster																																																										
7	2016	Savana	Body	Chime Alarm Control Module																																																										
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
7	2016	Savana	Body	Auxiliary Heater Control Module																																																										
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2016	Savana	Body	Parking Assist Control Module																																																										
7	2016	Savana	Body	Theft Deterrent Module				V	V																																																					
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2011	Express/Savana	Body	Body Control Module																																																									
8	2011	Express/Savana	Body	Digital Radio Receiver																																																									
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																									
8	2011	Express/Savana	Body	Passenger Presence System																																																									
8	2011	Express/Savana	Body	Radio																																																									
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
8	2011	Express/Savana	Body	Rollover Sensor																																																									
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
8	2011	Express/Savana	Body	Theft Deterrent Module																										V	V	V	V																												
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2011	Express Access/Savana Pro	Body	Body Control Module																																																									
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																									
8	2011	Express Access/Savana Pro	Body	Radio																																																									
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																									
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																										V	V	V	V																												
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2012	Express/Savana	Body	Body Control Module																																																									
8	2012	Express/Savana	Body	Digital Radio Receiver																																																									
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																									
8	2012	Express/Savana	Body	Passenger Presence System																																																									
8	2012	Express/Savana	Body	Radio																																																									
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
8	2012	Express/Savana	Body	Rollover Sensor																																																									
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
8	2012	Express/Savana	Body	Theft Deterrent Module																										V	V	V	V																												
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2012	Express Access/Savana Pro	Body	Body Control Module																																																									
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																									
8	2012	Express Access/Savana Pro	Body	Radio																																																									
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																									
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																										V	V	V	V																												
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2013	Express/Savana	Body	Body Control Module																																																									
8	2013	Express/Savana	Body	Digital Radio Receiver																																																									
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																									
8	2013	Express/Savana	Body	Navigation Radio																																																									
8	2013	Express/Savana	Body	Park Assist Module																																																									
8	2013	Express/Savana	Body	Passenger Presence System																																																									
8	2013	Express/Savana	Body	Radio																																																									
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
8	2013	Express/Savana	Body	Rollover Sensor																																																									
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
8	2013	Express/Savana	Body	Theft Deterrent Module																										V	V	V	V																												
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2013	Express Access/Savana Pro	Body	Body Control Module																																																										
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
8	2013	Express Access/Savana Pro	Body	Radio																																																										
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																										V	V	V	V																													
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
8	2014	Savana	Chassis	Electronic Brake Control Module																																																										
8	2014	Savana	Body	Body Control Module																																																										
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
8	2014	Savana	Body	Passenger Presence Module																																																										
8	2014	Savana	Body	Rollover Sensor Module																																																										
8	2014	Savana	Body	Instrument Cluster																																																										
8	2014	Savana	Body	Chime Alarm Control Module																																																										
8	2014	Savana	Body	Base Radio																																																										
8	2014	Savana	Body	Navigation Radio																																																										
8	2014	Savana	Body	Uplevel Radio																																																										
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
8	2014	Savana	Body	Auxiliary Heater Control Module																																																										
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
8	2014	Savana	Body	Parking Assist Control Module																																																										
8	2014	Savana	Body	Theft Deterrent Module				V	V																																																					
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
8	2015	Savana	Chassis	Electronic Brake Control Module																																																											
8	2015	Savana	Body	Body Control Module																																																										
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
8	2015	Savana	Body	Rollover Sensor Module																																																										
8	2015	Savana	Body	Instrument Cluster																																																										
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
8	2015	Savana	Body	Auxiliary Heater Control Module																																																										
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
8	2015	Savana	Body	Parking Assist Control Module																																																										
8	2015	Savana	Body	Theft Deterrent Module				V	V																																																						
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
8	2016	Savana	Chassis	Electronic Brake Control Module																																																										
8	2016	Savana	Body	Body Control Module																																																										
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
8	2016	Savana	Body	Instrument Cluster																																																										
8	2016	Savana	Body	Chime Alarm Control Module																																																										
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
8	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
8	2016	Savana	Body	Auxiliary Heater Control Module																																																										
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
8	2016	Savana	Body	Parking Assist Control Module																																																										
8	2016	Savana	Body	Theft Deterrent Module				V	V																																																					
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																										
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module											V																																														
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																										
ALL	2004	ALL	Chassis	ABS																																																									
ALL	2004	ALL	Chassis	Air Suspension																																																									
ALL	2004	ALL	Body	Amplifier (Bose)																																																									
ALL	2004	ALL	Body	Body Control Module																																																									
ALL	2004	ALL	Body	Digital Radio Receiver																																																									
ALL	2004	ALL	Body	Driver Door Module																																																									
ALL	2004	ALL	Body	Driver Seat Module																																																									
ALL	2004	ALL	Body	Heating and Air Conditioning																																																									
ALL	2004	ALL	Body	Instrument Panel Cluster																																																									
ALL	2004	ALL	Body	OnStar																																																									
ALL	2004	ALL	Body	Passenger Door Module																																																									

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
ALL	2004	ALL	Body	Uplevel Radio																																																										
ALL	2004	ALL	Body	Navigation Radio																																																										
ALL	2004	ALL	Body	Rear Seat Audio																																																										
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																										
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module											V																																														
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																										
ALL	2005	ALL	Chassis	ABS																																																										
ALL	2005	ALL	Chassis	Air Suspension																																																										
ALL	2005	ALL	Body	Body Control Module																																																										
ALL	2005	ALL	Body	Digital Radio Receiver																																																										
ALL	2005	ALL	Body	Driver Door Module (SUV)																																																										
ALL	2005	ALL	Body	Driver Door Module (SUT)																																																										
ALL	2005	ALL	Body	Driver Seat Module																																																										
ALL	2005	ALL	Body	Heating and Air Conditioning																																																										
ALL	2005	ALL	Body	Instrument Panel Cluster																																																										
ALL	2005	ALL	Body	Passenger Door Module																																																										
ALL	2005	ALL	Body	Uplevel Radio																																																										
ALL	2005	ALL	Body	Navigation Radio																																																										
ALL	2005	ALL	Body	Rear Seat Audio																																																										
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																										
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module											V																																														
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																										
ALL	2006	H2	Chassis	ABS																																																										
ALL	2006	H2	Chassis	Air Suspension																																																										
ALL	2006	H2	Body	Body Control Module																																																										
ALL	2006	H2	Body	Digital Radio Receiver																																																										
ALL	2006	H2	Body	Driver Door Module (SUV)																																																										
ALL	2006	H2	Body	Driver Door Module (SUT)																																																										
ALL	2006	H2	Body	Driver Seat Module																																																										
ALL	2006	H2	Body	Heating and Air Conditioning																																																										
ALL	2006	H2	Body	Instrument Panel Cluster																																																										
ALL	2006	H2	Body	Passenger Door Module																																																										
ALL	2006	H2	Body	Uplevel Radio																																																										
ALL	2006	H2	Body	Navigation Radio																																																										
ALL	2006	H2	Body	Rear Seat Audio																																																										
ALL	2006	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	H3	Powertrain	Engine Control Module																																																										
ALL	2006	H3	Powertrain	Transmission Control Module											V																																														
ALL	2006	H3	Powertrain	Transfer Case Control Module																																																										
ALL	2006	H3	Chassis	Antilock Brake System																																																										
ALL	2006	H3	Body	Body Control Module																																																										
ALL	2006	H3	Body	Digital Radio Receiver																																																										
ALL	2006	H3	Body	Instrument Panel Cluster																																																										
ALL	2006	H3	Body	Uplevel Radio																		V																																								
ALL	2006	H3	Body	Navigation Radio																																																										
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																										
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module											V																																														
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
ALL	2007	H2	Chassis	ABS																																																										
ALL	2007	H2	Chassis	Air Suspension																																																										
ALL	2007	H2	Body	Amplifier (Bose)																																																										
ALL	2007	H2	Body	Body Control Module																																																										
ALL	2007	H2	Body	Digital Radio Receiver																																																										
ALL	2007	H2	Body	Driver Door Module (SUV)																																																										
ALL	2007	H2	Body	Driver Door Module (SUT)																																																										
ALL	2007	H2	Body	Driver Seat Module																																																										
ALL	2007	H2	Body	HVAC Control Module																																																										
ALL	2007	H2	Body	Instrument Panel Cluster																																																										
ALL	2007	H2	Body	Passenger Door Module																																																										
ALL	2007	H2	Body	Uplevel Radio																																																										
ALL	2007	H2	Body	Navigation Radio																																																										
ALL	2007	H2	Body	Rear Seat Audio																																																										
ALL	2007	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																						V																																				
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module											V																																															
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																										
ALL	2007	H3	Chassis	EBCM																																																										
ALL	2007	H3	Body	Body Control Module (5GT)																																																										
ALL	2007	H3	Body	Body Control Module (ADM)																																																										
ALL	2007	H3	Body	Digital Radio Receiver																																																										
ALL	2007	H3	Body	Generator Battery Control Module																																																										
ALL	2007	H3	Body	Instrument Panel Cluster																																																										
ALL	2007	H3	Body	Personal Audio Link Module																																																										
ALL	2007	H3	Body	Uplevel Radio																		V																																								
ALL	2007	H3	Body	Navigation Radio																																																										
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2008	H2	Chassis	Air SCM																																																										
ALL	2008	H2	Chassis	EBCM																																																										
ALL	2008	H2	Body	Amplifier (Bose)																																																										
ALL	2008	H2	Body	Body Control Module																																																										
ALL	2008	H2	Body	Digital Radio Receiver																																																										
ALL	2008	H2	Body	Driver Door Switch																																																										
ALL	2008	H2	Body	HVAC Control Module																																																										
ALL	2008	H2	Body	Instrument Panel Cluster																																																										
ALL	2008	H2	Body	Memory Seat Module																																																										
ALL	2008	H2	Body	Passenger Door Switch																																																										
ALL	2008	H2	Body	Radio																																																										
ALL	2008	H2	Body	Rear Heated Seat Module																																																										
ALL	2008	H2	Body	Rear HVAC/RSA																																																										
ALL	2008	H2	Body	Rollover Sensor																																																										
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	H2	Body	Theft Deterrent Module																									V	V	V	V																														
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)																						V																																				
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																						V																																				
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																																										
ALL	2008	H3	Chassis	EBCM																																																										
ALL	2008	H3	Body	Body Control Module (5GT)																																																										
ALL	2008	H3	Body	Body Control Module (ADM)																																																										
ALL	2008	H3	Body	Digital Radio Receiver																																																										
ALL	2008	H3	Body	Generator Battery Control Module																																																										
ALL	2008	H3	Body	Instrument Panel Cluster																																																										
ALL	2008	H3	Body	Personal Audio Link Module																																																										
ALL	2008	H3	Body	Uplevel Radio																		V																																								
ALL	2008	H3	Body	Navigation Radio																																																										
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	H3	Body	Theft Deterrent Module																																																										
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2009	H2	Chassis	Air SCM																																																										
ALL	2009	H2	Chassis	EBCM																																																										
ALL	2009	H2	Body	Amplifier (Bose)																																																										
ALL	2009	H2	Body	Body Control Module																																																										
ALL	2009	H2	Body	Digital Radio Receiver																																																										
ALL	2009	H2	Body	Driver Door Switch																																																										
ALL	2009	H2	Body	HVAC Control Module																																																										
ALL	2009	H2	Body	Instrument Panel Cluster																																																										
ALL	2009	H2	Body	Memory Seat Module																																																										
ALL	2009	H2	Body	Passenger Door Switch																																																										
ALL	2009	H2	Body	Radio																																																										
ALL	2009	H2	Body	Rear Heated Seat Module																																																										
ALL	2009	H2	Body	Rear HVAC/RSA																																																										
ALL	2009	H2	Body	Rollover Sensor																																																										
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	H2	Body	Theft Deterrent Module																									V	V	V	V																														
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)																						V																																				
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																						V																																				
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2009	H3	Chassis	EBCM																																																										
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																																										
ALL	2009	H3	Body	Body Control Module (ADM)																																																										
ALL	2009	H3	Body	Digital Radio Receiver																																																										
ALL	2009	H3	Body	Generator Battery Control Module																																																										
ALL	2009	H3	Body	Instrument Panel Cluster																																																										
ALL	2009	H3	Body	Personal Audio Link Module																																																										
ALL	2009	H3	Body	Uplevel Radio																		V																																								
ALL	2009	H3	Body	Navigation Radio																																																										
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	H3	Body	Theft Deterrent Module																																																										
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2010	H2	Chassis	Air SCM																																																										
ALL	2010	H2	Chassis	EBCM																																																										
ALL	2010	H2	Body	Amplifier (Bose)																																																										
ALL	2010	H2	Body	Body Control Module																																																										
ALL	2010	H2	Body	Digital Radio Receiver																																																										
ALL	2010	H2	Body	Driver Door Switch																																																										
ALL	2010	H2	Body	HVAC Control Module																																																										
ALL	2010	H2	Body	Instrument Panel Cluster																																																										
ALL	2010	H2	Body	Memory Seat Module																																																										
ALL	2010	H2	Body	Passenger Door Switch																																																										
ALL	2010	H2	Body	Personal Audio Link Module																																																										
ALL	2010	H2	Body	Radio																																																										
ALL	2010	H2	Body	Rear Heated Seat Module																																																										
ALL	2010	H2	Body	Rear HVAC/RSA																																																										
ALL	2010	H2	Body	Rollover Sensor																																																										
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	H2	Body	Theft Deterrent Module																										V	V	V	V																													
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																						V																																				
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2010	H3	Chassis	EBCM																																																										
ALL	2010	H3	Body	Body Control Module																																																										
ALL	2010	H3	Body	Digital Radio Receiver																																																										
ALL	2010	H3	Body	Generator Battery Control Module																																																										
ALL	2010	H3	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Adjustable Pedals Data	Steering Column Softstops Learn	Steering Column Softstops Clear	Control Module Replacement Data	ECM Status Data	Key Fob Data	Keyless Entry Antenna - Center Console Active	Exterior Driver Side Keyless Entry Antenna	Exterior Passenger Side Keyless Entry Antenna	EGR Data	Clear TAP	Module Information 1	Module Information 2	A/C Information	HVAC Door Calibrations	Nav. Radio Theft	Cassette Information	CD Information	Long Wave	Military or Standard Time	Leveling Information	AIR Data	Navigation Voice	Invalidate all remote	Next available slot	TDM Data	Powertrain Status	Substitution Detection Data1	Substitution Detection Data2	Power Window Motor Programming	Stop/Start Capacitor State of Health Reset	Range Actuator	Range Actuator Learn	Rear Brake Caliper Piston Extend	Rear Brake Caliper Piston Retract	Battery Sensor Module Learn	Front Cameras Alignment Learn	Engineering Data 3	Engineering Data 4	Engineering Data 5	Engineering Data 6	Engineering Data 7	Liftgate Maximum Open Position Learn	Clear Secured High Voltage DTCs	Battery Charger Control Module Data	Charge History Data	Contactor Data	Hybrid Battery Pack Contactor Open Reasons	Hybrid/EV Battery Pack Active Cooling	Hybrid/EV Powertrain Control Module 2 Data	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	Hybrid/EV Battery Pack Capacity Learn	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	Fuel Economy Reset	Hybrid/EV Battery Contactor Open Reasons Reset	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
ALL	2010	H3	Body	Personal Audio Link Module																																																												
ALL	2010	H3	Body	Uplevel Radio																		V																																										
ALL	2010	H3	Body	Navigation Radio																																																												
ALL	2010	H3	Body	Supplemental Inflatable Restraint																																																												
ALL	2010	H3	Body	Theft Deterrent Module																																																												
ALL	2010	H3	Body	Vehicle Comm. Interface Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																													
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																													
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																													
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																													
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																													
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																													
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																													
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																													
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																													
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																													
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																													
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																													
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																													
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																													
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																													
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																													
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																													
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																													
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																													
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																													
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																													
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																													
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																													
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																													
C	2004	ALL	Chassis	ESC																																																													
C	2004	ALL	Chassis	Rear Wheel Steering																																																													
C	2004	ALL	Chassis	Tire Pressure Monitor																																																													
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																													
C	2004	ALL	Chassis	VSES																																																													
C	2004	ALL	Body	Amplifier (Bose)																																																													
C	2004	ALL	Body	Body Control Module																																																													
C	2004	ALL	Body	CD Changer																																																													
C	2004	ALL	Body	Chime																																																													
C	2004	ALL	Body	Driver Door Module																																																													
C	2004	ALL	Body	Driver Seat Module																																																													
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																													
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																													
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																													
C	2004	ALL	Body	Instrument Panel Cluster																																																													
C	2004	ALL	Body	OnStar																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2004	ALL	Body	Passenger Door Module																																																														
C	2004	ALL	Body	Passenger Presence System																																																															
C	2004	ALL	Body	Radio Base																																																															
C	2004	ALL	Body	Radio Uplevel																																																															
C	2004	ALL	Body	Radio Navigation																																																															
C	2004	ALL	Body	Rear Aux. Climate Module																																																															
C	2004	ALL	Body	Rear HVAC																																																															
C	2004	ALL	Body	Rear Seat Audio																																																															
C	2004	ALL	Body	Rear Seat Entertainment																																																															
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																															
C	2004	ALL	Body	Vehicle Theft Deterrent																																																															
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																																
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																																
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																																
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																																
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																																
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																																
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																																
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																																
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																																
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																																
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																																
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																																
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																																
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																																
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																																
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																																
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																																
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																																
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																																
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																																
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																																
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																																
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																																
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																																
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																																
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																																
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																																
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																																
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																																
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																																
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																																
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																																
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																																
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																																
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																																
C	2005	ALL	Chassis	ESC																																																																
C	2005	ALL	Chassis	Rear Wheel Steering																																																																
C	2005	ALL	Chassis	Tire Pressure Monitor																																																																
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																																
C	2005	ALL	Chassis	VSES																																																																

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2005	ALL	Body	Amplifier (Bose)																																																														
C	2005	ALL	Body	Body Control Module																																																														
C	2005	ALL	Body	CD Changer																																																														
C	2005	ALL	Body	Chime																																																														
C	2005	ALL	Body	Disc Player and Video Display																																																														
C	2005	ALL	Body	Driver Door Module																																																														
C	2005	ALL	Body	Driver Seat Module																																																														
C	2005	ALL	Body	Generator Battery Control Module																																																														
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																														
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																														
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																														
C	2005	ALL	Body	Instrument Panel Cluster																																																														
C	2005	ALL	Body	Passenger Door Module																																																														
C	2005	ALL	Body	Passenger Presence System																																																														
C	2005	ALL	Body	Base Radio																																																														
C	2005	ALL	Body	Uplevel Radio																																																														
C	2005	ALL	Body	Navigation Radio																																																														
C	2005	ALL	Body	Rear Aux. Climate Module																																																														
C	2005	ALL	Body	Rear HVAC																																																														
C	2005	ALL	Body	Rear Seat Audio																																																														
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																														
C	2005	ALL	Body	Vehicle Theft Deterrent																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																														
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																														
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																														
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																													
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																													
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																													
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																													
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																													
C	2006	ALL	Chassis	ESC																																																													
C	2006	ALL	Chassis	Tire Pressure Monitor																																																													
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																													
C	2006	ALL	Chassis	VSES																																																													
C	2006	ALL	Body	Amplifier (Bose)																																																													
C	2006	ALL	Body	Body Control Module																																																													
C	2006	ALL	Body	CD Changer																																																													
C	2006	ALL	Body	Chime																																																													
C	2006	ALL	Body	Disc Player and Video Display																																																													
C	2006	ALL	Body	Driver Door Module																																																													
C	2006	ALL	Body	Driver Seat Module																																																													
C	2006	ALL	Body	Generator Battery Control Module																																																													
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																													
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																													
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																													
C	2006	ALL	Body	Instrument Panel Cluster																																																													
C	2006	ALL	Body	Passenger Door Module																																																													
C	2006	ALL	Body	Passenger Presence System																																																													
C	2006	ALL	Body	Base Radio																																																												
C	2006	ALL	Body	Uplevel Radio																																																												
C	2006	ALL	Body	Navigation Radio																																																												
C	2006	ALL	Body	Rear Aux. Climate Module																																																												
C	2006	ALL	Body	Rear HVAC																																																												
C	2006	ALL	Body	Rear Seat Audio																																																												
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2006	ALL	Body	Vehicle Theft Deterrent																																																												
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																		
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																		
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								V																		
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																		
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																		
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																			
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																			
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																			
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																			
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																			
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Sierra	Chassis	Electronic Suspension Control																																																												
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2007	Sierra	Body	Amplifier (Bose)																																																												
C	2007	Sierra	Body	Body Control Module																																																												
C	2007	Sierra	Body	Body Control Module (aux.)																																																												
C	2007	Sierra	Body	Digital Radio Receiver																																																												
C	2007	Sierra	Body	Driver Door Switch																																																												
C	2007	Sierra	Body	HVAC Control Module Auto																																																												
C	2007	Sierra	Body	HVAC Control Module Manual																																																												
C	2007	Sierra	Body	Instrument Panel Cluster																																																												
C	2007	Sierra	Body	Memory Seat Module																																																												
C	2007	Sierra	Body	Park Assist Module																																																												
C	2007	Sierra	Body	Passenger Door Switch																																																												
C	2007	Sierra	Body	Passenger Presence System																																																												
C	2007	Sierra	Body	Radio																																																											
C	2007	Sierra	Body	Rear Heated Seat Module																																																												
C	2007	Sierra	Body	Rear HVAC/RSA																																																												
C	2007	Sierra	Body	Rollover Sensor																																																												
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2007	Sierra	Body	Theft Deterrent Module																																																												
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																			
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																			
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																			
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																			
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Yukon	Chassis	Electronic Suspension Control																																																												
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																												
C	2007	Yukon	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2007	Yukon	Body	Assist Step Controller																																																														
C	2007	Yukon	Body	Body Control Module																																																															
C	2007	Yukon	Body	Body Control Module (aux.)																																																															
C	2007	Yukon	Body	Digital Radio Receiver																																																															
C	2007	Yukon	Body	Driver Door Switch																																																															
C	2007	Yukon	Body	HVAC Control Module Auto																																																															
C	2007	Yukon	Body	HVAC Control Module Manual																																																															
C	2007	Yukon	Body	Instrument Panel Cluster																																																															
C	2007	Yukon	Body	Lift Gate Module																																																															
C	2007	Yukon	Body	Memory Seat Module																																																															
C	2007	Yukon	Body	Park Assist Module																																																															
C	2007	Yukon	Body	Passenger Door Switch																																																															
C	2007	Yukon	Body	Passenger Presence System																																																															
C	2007	Yukon	Body	Radio																																																															
C	2007	Yukon	Body	Rear Heated Seat Module																																																															
C	2007	Yukon	Body	Rear HVAC/RSA																																																															
C	2007	Yukon	Body	Rollover Sensor																																																															
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																																															
C	2007	Yukon	Body	Theft Deterrent Module																																																															
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																						
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																															
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																						
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																															
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																						
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																															
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																						
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																															
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																						
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																						
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																															
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																															
C	2007	Yukon XL	Body	Amplifier (Bose)																																																															
C	2007	Yukon XL	Body	Assist Step Controller																																																															
C	2007	Yukon XL	Body	Body Control Module																																																															
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																															
C	2007	Yukon XL	Body	Digital Radio Receiver																																																															
C	2007	Yukon XL	Body	Driver Door Switch																																																															
C	2007	Yukon XL	Body	HVAC Control Module Auto																																																															
C	2007	Yukon XL	Body	HVAC Control Module Manual																																																															
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																															
C	2007	Yukon XL	Body	Lift Gate Module																																																															
C	2007	Yukon XL	Body	Memory Seat Module																																																															
C	2007	Yukon XL	Body	Park Assist Module																																																															
C	2007	Yukon XL	Body	Passenger Door Switch																																																															
C	2007	Yukon XL	Body	Passenger Presence System																																																															
C	2007	Yukon XL	Body	Radio																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2007	Yukon XL	Body	Rear Heated Seat Module																																																														
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																														
C	2007	Yukon XL	Body	Rollover Sensor																																																														
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																														
C	2007	Yukon XL	Body	Theft Deterrent Module																																																														
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																					
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																														
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																														
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																					
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								V																					
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																					
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																					
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																					
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																														
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																					
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																														
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																														
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																					
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																														
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																					
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																					
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2008	Sierra	Chassis	Electronic Suspension Control																																																															
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																															
C	2008	Sierra	Body	Amplifier (Bose)																																																															
C	2008	Sierra	Body	Body Control Module																																																															
C	2008	Sierra	Body	Body Control Module (aux.)																																																															
C	2008	Sierra	Body	Digital Radio Receiver																																																															
C	2008	Sierra	Body	Driver Door Switch																																																															
C	2008	Sierra	Body	HVAC Control Module Auto																																																															
C	2008	Sierra	Body	HVAC Control Module Manual																																																															
C	2008	Sierra	Body	Instrument Panel Cluster																																																															
C	2008	Sierra	Body	Memory Seat Module																																																															
C	2008	Sierra	Body	Park Assist Module																																																															
C	2008	Sierra	Body	Passenger Door Switch																																																															
C	2008	Sierra	Body	Passenger Presence System																																																															
C	2008	Sierra	Body	Radio																																																															
C	2008	Sierra	Body	Rear Heated Seat Module																																																															
C	2008	Sierra	Body	Rear HVAC/RSA																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2008	Sierra	Body	Rollover Sensor																																																														
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																																														
C	2008	Sierra	Body	Theft Deterrent Module																																																														
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																					
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																					
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																														
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																					
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																														
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																														
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																					
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2008	Yukon	Chassis	Electronic Brake Control Module																																																														
C	2008	Yukon	Chassis	Electronic Suspension Control																																																														
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																														
C	2008	Yukon	Body	Amplifier (Bose)																																																														
C	2008	Yukon	Body	Assist Step Controller																																																														
C	2008	Yukon	Body	Body Control Module																																																														
C	2008	Yukon	Body	Body Control Module (aux.)																																																														
C	2008	Yukon	Body	Digital Radio Receiver																																																														
C	2008	Yukon	Body	Driver Door Switch																																																														
C	2008	Yukon	Body	HVAC Control Module Auto																																																														
C	2008	Yukon	Body	HVAC Control Module Manual																																																														
C	2008	Yukon	Body	Instrument Panel Cluster																																																														
C	2008	Yukon	Body	Lift Gate Module																																																														
C	2008	Yukon	Body	Memory Seat Module																																																														
C	2008	Yukon	Body	Park Assist Module																																																														
C	2008	Yukon	Body	Passenger Door Switch																																																														
C	2008	Yukon	Body	Passenger Presence System																																																														
C	2008	Yukon	Body	Radio																																																														
C	2008	Yukon	Body	Rear Heated Seat Module																																																														
C	2008	Yukon	Body	Rear HVAC/RSA																																																														
C	2008	Yukon	Body	Rollover Sensor																																																														
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																																														
C	2008	Yukon	Body	Theft Deterrent Module																																																														
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																					
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																														
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																														
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																														
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																														
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																														
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																														
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																														
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																														
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																														
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																														
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																														
C	2008	Yukon Hybrid	Body	Body Control Module																																																														
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																														
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																														
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																														
C	2008	Yukon Hybrid	Body	HVAC Control Module																																																														
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																														
C	2008	Yukon Hybrid	Body	Lift Gate Module																																																														
C	2008	Yukon Hybrid	Body	Memory Seat Module																																																														
C	2008	Yukon Hybrid	Body	Park Assist Module																																																														
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																														
C	2008	Yukon Hybrid	Body	Passenger Presence System																																																														
C	2008	Yukon Hybrid	Body	Radio																																																														
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																														
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																														
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																														
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																														
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																														
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																														
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																					
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																														
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																														
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																					
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																					
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																					
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																														
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																														
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																					
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																					
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																														
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																														
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																														
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																														
C	2008	Yukon XL	Body	Amplifier (Bose)																																																														
C	2008	Yukon XL	Body	Assist Step Controller																																																														
C	2008	Yukon XL	Body	Body Control Module																																																														
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																														
C	2008	Yukon XL	Body	Digital Radio Receiver																																																														
C	2008	Yukon XL	Body	Driver Door Switch																																																														
C	2008	Yukon XL	Body	HVAC Control Module Auto																																																														
C	2008	Yukon XL	Body	HVAC Control Module Manual																																																														
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																														
C	2008	Yukon XL	Body	Lift Gate Module																																																														
C	2008	Yukon XL	Body	Memory Seat Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2008	Yukon XL	Body	Park Assist Module																																																														
C	2008	Yukon XL	Body	Passenger Door Switch																																																														
C	2008	Yukon XL	Body	Passenger Presence System																																																														
C	2008	Yukon XL	Body	Radio																																																														
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																														
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																														
C	2008	Yukon XL	Body	Rollover Sensor																																																														
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																														
C	2008	Yukon XL	Body	Theft Deterrent Module																																																														
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																					
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																					
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								V																					
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																					
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																														
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																					
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																					
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																					
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																														
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																					
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								V																					
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual																																								V																					
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																														
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																														
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																														
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																														
C	2009	Sierra	Chassis	Electronic Suspension Control																																																														
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																														
C	2009	Sierra	Body	Amplifier (Bose)																																																														
C	2009	Sierra	Body	Body Control Module																																																														
C	2009	Sierra	Body	Body Control Module (aux.)																																																														
C	2009	Sierra	Body	Digital Radio Receiver																																																														
C	2009	Sierra	Body	Driver Door Switch																																																														
C	2009	Sierra	Body	HVAC Control Module Auto																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2009	Sierra	Body	HVAC Control Module Manual																																																												
C	2009	Sierra	Body	Instrument Panel Cluster																																																												
C	2009	Sierra	Body	Memory Seat Module																																																												
C	2009	Sierra	Body	Park Assist Module																																																												
C	2009	Sierra	Body	Passenger Door Switch																																																												
C	2009	Sierra	Body	Passenger Presence System																																																												
C	2009	Sierra	Body	Radio																																																												
C	2009	Sierra	Body	Rear Heated Seat Module																																																												
C	2009	Sierra	Body	Rear HVAC/RSA																																																												
C	2009	Sierra	Body	Rollover Sensor																																																												
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2009	Sierra	Body	Theft Deterrent Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																				
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																												
C	2009	Sierra Hybrid	Body	Body Control Module																																																												
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																												
C	2009	Sierra Hybrid	Body	Driver Door Switch																																																												
C	2009	Sierra Hybrid	Body	HVAC Control Module																																																												
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
C	2009	Sierra Hybrid	Body	Memory Seat Module																																																												
C	2009	Sierra Hybrid	Body	Park Assist Module																																																												
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																																												
C	2009	Sierra Hybrid	Body	Passenger Presence System																																																												
C	2009	Sierra Hybrid	Body	Radio																																																												
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																												
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed																																								V																				
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed																																								V																				
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																				
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																		
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								V																		
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed																																								V																		
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed																																								V																		
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
C	2009	Yukon	Chassis	Electronic Brake Control Module																																																										
C	2009	Yukon	Chassis	Electronic Suspension Control																																																										
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																										
C	2009	Yukon	Body	Amplifier (Bose)																																																										
C	2009	Yukon	Body	Assist Step Controller																																																										
C	2009	Yukon	Body	Body Control Module																																																										
C	2009	Yukon	Body	Body Control Module (aux.)																																																										
C	2009	Yukon	Body	Digital Radio Receiver																																																										
C	2009	Yukon	Body	Driver Door Switch																																																										
C	2009	Yukon	Body	HVAC Control Module Auto																																																										
C	2009	Yukon	Body	HVAC Control Module Manual																																																										
C	2009	Yukon	Body	Instrument Panel Cluster																																																										
C	2009	Yukon	Body	Left Side Object Detection Module																																																										
C	2009	Yukon	Body	Lift Gate Module																																																										
C	2009	Yukon	Body	Memory Seat Module																																																										
C	2009	Yukon	Body	Park Assist Module																																																										
C	2009	Yukon	Body	Passenger Door Switch																																																										
C	2009	Yukon	Body	Passenger Presence System																																																										
C	2009	Yukon	Body	Radio																																																										
C	2009	Yukon	Body	Rear Heated Seat Module																																																										
C	2009	Yukon	Body	Rear HVAC/RSA																																																										
C	2009	Yukon	Body	Right Side Object Detection Module																																																										
C	2009	Yukon	Body	Rollover Sensor																																																										
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																																										
C	2009	Yukon	Body	Theft Deterrent Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																		
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																										
C	2009	Yukon Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																															
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																															
C	2009	Yukon Hybrid	Body	Driver Door Switch																																																															
C	2009	Yukon Hybrid	Body	Heated Seat Module																																																															
C	2009	Yukon Hybrid	Body	HVAC Control Module																																																															
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																															
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																															
C	2009	Yukon Hybrid	Body	Park Assist Module																																																															
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																																															
C	2009	Yukon Hybrid	Body	Passenger Presence System																																																															
C	2009	Yukon Hybrid	Body	Radio																																																															
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																															
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																															
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																															
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																															
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																															
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																															
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																															
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																						
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																															
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																															
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																						
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																															
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																						
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																															
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																															
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																						
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								V																						
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																						
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																															
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																															
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																															
C	2009	Yukon XL	Body	Amplifier (Bose)																																																															
C	2009	Yukon XL	Body	Assist Step Controller																																																															
C	2009	Yukon XL	Body	Body Control Module																																																															
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																															
C	2009	Yukon XL	Body	Digital Radio Receiver																																																															
C	2009	Yukon XL	Body	Driver Door Switch																																																															
C	2009	Yukon XL	Body	HVAC Control Module Auto																																																															
C	2009	Yukon XL	Body	HVAC Control Module Manual																																																															
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																															
C	2009	Yukon XL	Body	Left Side Object Detection Module																																																															
C	2009	Yukon XL	Body	Lift Gate Module																																																															
C	2009	Yukon XL	Body	Memory Seat Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2009	Yukon XL	Body	Park Assist Module																																																														
C	2009	Yukon XL	Body	Passenger Door Switch																																																														
C	2009	Yukon XL	Body	Passenger Presence System																																																														
C	2009	Yukon XL	Body	Radio																																																														
C	2009	Yukon XL	Body	Rear Heated Seat Module																																																														
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																														
C	2009	Yukon XL	Body	Right Side Object Detection Module																																																														
C	2009	Yukon XL	Body	Rollover Sensor																																																														
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																														
C	2009	Yukon XL	Body	Theft Deterrent Module																																																														
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																														
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																														
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																														
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																						
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																														
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																						
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																						
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																														
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																														
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																														
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																														
C	2010	Sierra	Chassis	Electronic Suspension Control																																																														
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																														
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Sierra	Body	Amplifier (Bose)																																																														
C	2010	Sierra	Body	Body Control Module																																																														
C	2010	Sierra	Body	Body Control Module (aux.)																																																														
C	2010	Sierra	Body	Digital Radio Receiver																																																														
C	2010	Sierra	Body	Driver Door Switch																																																														
C	2010	Sierra	Body	HVAC Control Module Auto																																																														
C	2010	Sierra	Body	HVAC Control Module Manual																																																														
C	2010	Sierra	Body	Instrument Panel Cluster																																																														
C	2010	Sierra	Body	Memory Seat Module																																																														
C	2010	Sierra	Body	Park Assist Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2010	Sierra	Body	Passenger Door Switch																																																														
C	2010	Sierra	Body	Passenger Presence System																																																														
C	2010	Sierra	Body	Radio																																																													
C	2010	Sierra	Body	Rear Heated Seat Module																																																													
C	2010	Sierra	Body	Rear HVAC/RSA																																																													
C	2010	Sierra	Body	Supplemental Inflatable Restraint																																																													
C	2010	Sierra	Body	Theft Deterrent Module																																																													
C	2010	Sierra Hybrid	Powertrain	Engine Control Module																																								V																				
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																													
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																													
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																													
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																													
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																													
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																													
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																													
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																													
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																													
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																													
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																													
C	2010	Sierra Hybrid	Body	Body Control Module																																																													
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																													
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																													
C	2010	Sierra Hybrid	Body	Driver Door Switch																																																													
C	2010	Sierra Hybrid	Body	Heated Seat Module																																																													
C	2010	Sierra Hybrid	Body	HVAC Control Module																																																													
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																													
C	2010	Sierra Hybrid	Body	Park Assist Module																																																													
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																																													
C	2010	Sierra Hybrid	Body	Passenger Presence System																																																													
C	2010	Sierra Hybrid	Body	Radio																																																													
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																													
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																													
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																													
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																													
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																													
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								V																				
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																													
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																				
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2010	Yukon	Chassis	Electronic Brake Control Module																																																													
C	2010	Yukon	Chassis	Electronic Suspension Control																																																													
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Yukon	Body	Amplifier (Bose)																																																													
C	2010	Yukon	Body	Assist Step Controller																																																													
C	2010	Yukon	Body	Body Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2010	Yukon	Body	Body Control Module (aux.)																																																														
C	2010	Yukon	Body	Digital Radio Receiver																																																														
C	2010	Yukon	Body	Driver Door Switch																																																														
C	2010	Yukon	Body	HVAC Control Module Auto																																																														
C	2010	Yukon	Body	HVAC Control Module Manual																																																														
C	2010	Yukon	Body	Instrument Panel Cluster																																																														
C	2010	Yukon	Body	Left Side Object Detection Module																																																														
C	2010	Yukon	Body	Lift Gate Module																																																														
C	2010	Yukon	Body	Memory Seat Module																																																														
C	2010	Yukon	Body	Park Assist Module																																																														
C	2010	Yukon	Body	Passenger Door Switch																																																														
C	2010	Yukon	Body	Passenger Presence System																																																														
C	2010	Yukon	Body	Radio																																																														
C	2010	Yukon	Body	Rear Heated Seat Module																																																														
C	2010	Yukon	Body	Rear HVAC/RSA																																																														
C	2010	Yukon	Body	Right Side Object Detection Module																																																														
C	2010	Yukon	Body	Supplemental Inflatable Restraint																																																														
C	2010	Yukon	Body	Theft Deterrent Module																																																														
C	2010	Yukon Hybrid	Powertrain	Engine Control Module																																								V																					
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																														
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																														
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																														
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																														
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																														
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																														
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																														
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																														
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																														
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																														
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																														
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																														
C	2010	Yukon Hybrid	Body	Body Control Module																																																														
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																														
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																														
C	2010	Yukon Hybrid	Body	Driver Door Switch																																																														
C	2010	Yukon Hybrid	Body	Heated Seat Module																																																														
C	2010	Yukon Hybrid	Body	HVAC Control Module																																																														
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																														
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																														
C	2010	Yukon Hybrid	Body	Lift Gate Module																																																														
C	2010	Yukon Hybrid	Body	Park Assist Module																																																														
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																																														
C	2010	Yukon Hybrid	Body	Passenger Presence System																																																														
C	2010	Yukon Hybrid	Body	Radio																																																														
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																														
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																														
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																														
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																														
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																													
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								V																					
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																					
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																					
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																															
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																															
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																															
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																															
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																															
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																															
C	2010	Yukon XL	Body	Amplifier (Bose)																																																															
C	2010	Yukon XL	Body	Assist Step Controller																																																															
C	2010	Yukon XL	Body	Body Control Module																																																															
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																															
C	2010	Yukon XL	Body	Digital Radio Receiver																																																															
C	2010	Yukon XL	Body	Driver Door Switch																																																															
C	2010	Yukon XL	Body	HVAC Control Module Auto																																																															
C	2010	Yukon XL	Body	HVAC Control Module Manual																																																															
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																															
C	2010	Yukon XL	Body	Left Side Object Detection Module																																																															
C	2010	Yukon XL	Body	Lift Gate Module																																																															
C	2010	Yukon XL	Body	Memory Seat Module																																																															
C	2010	Yukon XL	Body	Park Assist Module																																																															
C	2010	Yukon XL	Body	Passenger Door Switch																																																															
C	2010	Yukon XL	Body	Passenger Presence System																																																															
C	2010	Yukon XL	Body	Radio																																																															
C	2010	Yukon XL	Body	Rear Heated Seat Module																																																															
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																															
C	2010	Yukon XL	Body	Right Side Object Detection Module																																																															
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																															
C	2010	Yukon XL	Body	Theft Deterrent Module																																																															
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																								V																					
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																															
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																															
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																															
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																															
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																															
D	2008	ALL	Chassis	Electronic Brake Control Module																																									V																					
D	2008	ALL	Body	Body Control Module																																																															
D	2008	ALL	Body	Body Control Module (aux.)																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
D	2008	ALL	Body	Headlamp Control Module																																																														
D	2008	ALL	Body	HVAC Control Module Auto																																																														
D	2008	ALL	Body	Instrument Panel Cluster																																																														
D	2008	ALL	Body	Park Assist Module																																																														
D	2008	ALL	Body	Remote Control Door Lock Receiver																																																														
D	2008	ALL	Body	Supplemental Inflatable Restraint																																																														
D	2008	ALL	Body	Theft Deterrent Module																																																														
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																								V																					
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																														
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																														
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																														
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																														
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																														
D	2009	ALL	Chassis	Electronic Brake Control Module																																									V																					
D	2009	ALL	Body	Body Control Module																																																														
D	2009	ALL	Body	Body Control Module (aux.)																																																														
D	2009	ALL	Body	Headlamp Control Module																																																														
D	2009	ALL	Body	HVAC Control Module Auto																																																														
D	2009	ALL	Body	Instrument Panel Cluster																																																														
D	2009	ALL	Body	Park Assist Module																																																														
D	2009	ALL	Body	Remote Control Door Lock Receiver																																																														
D	2009	ALL	Body	Supplemental Inflatable Restraint																																																														
D	2009	ALL	Body	Theft Deterrent Module																																																														
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																								V																					
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																														
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																														
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																														
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																														
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																														
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																														
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																														
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																														
D	2010	ALL	Chassis	Electronic Brake Control Module																																									V																					
D	2010	ALL	Body	Body Control Module																																																														
D	2010	ALL	Body	Body Control Module (aux.)																																																														
D	2010	ALL	Body	Headlamp Control Module																																																														
D	2010	ALL	Body	HVAC Control Module Auto																																																														
D	2010	ALL	Body	Instrument Panel Cluster																																																														
D	2010	ALL	Body	Park Assist Module																																																														
D	2010	ALL	Body	Remote Control Door Lock Receiver																																																														
D	2010	ALL	Body	Supplemental Inflatable Restraint																																																														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																														
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																														
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																												
G	2004	Express/Savana	Chassis	VSES																																																												
G	2004	Express/Savana	Body	Body Control Module																																																												
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																												
G	2004	Express/Savana	Body	OnStar																																																												
G	2004	Express/Savana	Body	Base Radio																																																												
G	2004	Express/Savana	Body	Uplevel Radio																																																												
G	2004	Express/Savana	Body	Remote Function Actuation																																																												
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																													
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																													
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																													
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																													
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																													
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																													
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																													
G	2004	Express Access/Savana Pro	Chassis	VSES																																																													
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																													
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																													
G	2004	Express Access/Savana Pro	Body	OnStar																																																													
G	2004	Express Access/Savana Pro	Body	Base Radio																																																													
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																													
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																													
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																												
G	2005	Express/Savana	Chassis	VSES																																																												
G	2005	Express/Savana	Body	Body Control Module																																																												
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																												
G	2005	Express/Savana	Body	Base Radio																																																												
G	2005	Express/Savana	Body	Uplevel Radio																																																												
G	2005	Express/Savana	Body	Remote Function Actuation																																																												
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
G	2005	Express Access/Savana Pro	Chassis	VSES																																																												
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
G	2005	Express Access/Savana Pro	Body	Base Radio																																																												
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																												
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																												
G	2006	Express/Savana	Chassis	VSES																																																												
G	2006	Express/Savana	Body	Body Control Module																																																												
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																												
G	2006	Express/Savana	Body	Passenger Presence System																																																												
G	2006	Express/Savana	Body	Base Radio																																																												
G	2006	Express/Savana	Body	Uplevel Radio																																																												
G	2006	Express/Savana	Body	Remote Function Actuation																																																												
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
G	2006	Express Access/Savana Pro	Chassis	VSES																																																												
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2006	Express Access/Savana Pro	Body	Base Radio																																																												
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																												
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																											
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																									V																			
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																												
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																												
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2007	Express/Savana	Body	Body Control Module																																																												
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																												
G	2007	Express/Savana	Body	Passenger Presence System																																																												
G	2007	Express/Savana	Body	Base Radio																																																												
G	2007	Express/Savana	Body	Uplevel Radio																																																												
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																									V																			

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																													
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																												
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2007	Express Access/Savana Pro	Body	Radio																																																												
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																			
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																			
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								V																			
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																			
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																			
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2008	Express/Savana	Body	Body Control Module																																																												
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2008	Express/Savana	Body	Passenger Presence System																																																												
G	2008	Express/Savana	Body	Radio																																																											
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2008	Express/Savana	Body	Rollover Sensor																																																												
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2008	Express/Savana	Body	Theft Deterrent Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																			
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																			
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								V																			
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																			
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																			
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																														
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																														
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																														
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																														
G	2008	Express Access/Savana Pro	Body	Radio																																																														
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																														
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																														
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																														
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																					
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																					
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								V																					
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																														
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																														
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																														
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																														
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																					
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																														
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																														
G	2009	Express/Savana	Body	Body Control Module																																																														
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																														
G	2009	Express/Savana	Body	Passenger Presence System																																																														
G	2009	Express/Savana	Body	Radio																																																														
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																														
G	2009	Express/Savana	Body	Rollover Sensor																																																														
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																														
G	2009	Express/Savana	Body	Theft Deterrent Module																																																														
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																					
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																					
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								V																					
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																														
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																														
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																														
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																														
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																					
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																														
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																														
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																														
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																														
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																														
G	2009	Express Access/Savana Pro	Body	Radio																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																														
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																														
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																													
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																									V																				
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																									V																				
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2010	Express/Savana	Body	Body Control Module																																																													
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2010	Express/Savana	Body	Passenger Presence System																																																													
G	2010	Express/Savana	Body	Radio																																																												
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
G	2010	Express/Savana	Body	Rollover Sensor																																																													
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
G	2010	Express/Savana	Body	Theft Deterrent Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																									V																				
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																									V																				
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																															
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																															
G	2010	Express Access/Savana Pro	Body	Radio																																																															
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																															
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																															
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																															
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																															
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																															
H	2004	Express/Savana	Chassis	VSES																																																															
H	2004	Express/Savana	Body	Body Control Module																																																															
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																															
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																															
H	2004	Express/Savana	Body	OnStar																																																															
H	2004	Express/Savana	Body	Base Radio																																																															
H	2004	Express/Savana	Body	Uplevel Radio																																																															
H	2004	Express/Savana	Body	Remote Function Actuation																																																															
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																															
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																															
H	2004	Express Access/Savana Pro	Chassis	VSES																																																															
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																															
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																															
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																															
H	2004	Express Access/Savana Pro	Body	OnStar																																																															
H	2004	Express Access/Savana Pro	Body	Base Radio																																																															
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																															
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																															
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																															
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																															
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																															
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																															
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																															
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																															
H	2005	Express/Savana	Chassis	VSES																																																															
H	2005	Express/Savana	Body	Body Control Module																																																															
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																															
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																															
H	2005	Express/Savana	Body	Base Radio																																																															
H	2005	Express/Savana	Body	Uplevel Radio																																																															
H	2005	Express/Savana	Body	Remote Function Actuation																																																															
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																															
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																															
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																															
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																															
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																															
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																															
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																															
H	2005	Express Access/Savana Pro	Chassis	VSES																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																															
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																															
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																															
H	2005	Express Access/Savana Pro	Body	Base Radio																																																															
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																															
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																															
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																															
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																															
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																															
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																															
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																															
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																															
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																															
H	2006	Express/Savana	Chassis	VSES																																																															
H	2006	Express/Savana	Body	Body Control Module																																																															
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																															
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																															
H	2006	Express/Savana	Body	Passenger Presence System																																																															
H	2006	Express/Savana	Body	Base Radio																																																															
H	2006	Express/Savana	Body	Uplevel Radio																																																															
H	2006	Express/Savana	Body	Remote Function Actuation																																																															
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																															
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																															
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																															
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																															
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																															
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																															
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																															
H	2006	Express Access/Savana Pro	Chassis	VSES																																																															
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																															
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																															
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																															
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																															
H	2006	Express Access/Savana Pro	Body	Base Radio																																																															
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																															
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																															
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																															
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																															
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																															
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																															
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																															
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																															
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																															
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																															
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																															
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																															
H	2007	Express/Savana	Body	Body Control Module																																																															
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																															
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																															
H	2007	Express/Savana	Body	Passenger Presence System																																																															
H	2007	Express/Savana	Body	Base Radio																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2007	Express/Savana	Body	Uplevel Radio																																																												
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2007	Express Access/Savana Pro	Body	Base Radio																																																												
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																									V																			
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																									V																			
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																									V																			
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																									V																			
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2008	Express/Savana	Body	Body Control Module																																																												
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2008	Express/Savana	Body	Passenger Presence System																																																												
H	2008	Express/Savana	Body	Radio																																																												
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2008	Express/Savana	Body	Rollover Sensor																																																												
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2008	Express/Savana	Body	Theft Deterrent Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																									V																			
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																									V																			
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																									V																			
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																									V																			
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2008	Express Access/Savana Pro	Body	Radio																																																												
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																									V																			
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																										V																		
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																										V																		
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2009	Express/Savana	Body	Body Control Module																																																												
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2009	Express/Savana	Body	Passenger Presence System																																																												
H	2009	Express/Savana	Body	Radio																																																												
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2009	Express/Savana	Body	Rollover Sensor																																																												
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2009	Express/Savana	Body	Theft Deterrent Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																									V																			
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																									V																			
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																									V																			
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2009	Express Access/Savana Pro	Body	Radio																																																												
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2010	Express/Savana	Body	Body Control Module																																																												
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2010	Express/Savana	Body	Passenger Presence System																																																												
H	2010	Express/Savana	Body	Radio																																																												
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2010	Express/Savana	Body	Rollover Sensor																																																												
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2010	Express/Savana	Body	Theft Deterrent Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2010	Express Access/Savana Pro	Body	Radio																																																												
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																															
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																															
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																															
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																															
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																															
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																															
K	2004	ALL	Chassis	ESC																																																															
K	2004	ALL	Chassis	Rear Wheel Steering																																																															
K	2004	ALL	Chassis	Tire Pressure Monitor																																																															
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																															
K	2004	ALL	Chassis	VSES																																																															
K	2004	ALL	Body	Amplifier (Bose)																																																															
K	2004	ALL	Body	Body Control Module																																																															
K	2004	ALL	Body	CD Changer																																																															
K	2004	ALL	Body	Chime																																																															
K	2004	ALL	Body	Driver Door Module																																																															
K	2004	ALL	Body	Driver Seat Module																																																															
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																															
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																															
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																															
K	2004	ALL	Body	Instrument Panel Cluster																																																															
K	2004	ALL	Body	OnStar																																																															
K	2004	ALL	Body	Passenger Door Module																																																															
K	2004	ALL	Body	Passenger Presence System																																																															
K	2004	ALL	Body	Radio Base																																																															
K	2004	ALL	Body	Radio Uplevel																																																															
K	2004	ALL	Body	Radio Navigation																																																															
K	2004	ALL	Body	Rear Aux. Climate Module																																																															
K	2004	ALL	Body	Rear HVAC																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2004	ALL	Body	Rear Seat Audio																																																														
K	2004	ALL	Body	Rear Seat Entertainment																																																														
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																													
K	2004	ALL	Body	Vehicle Theft Deterrent																																																													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																													
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																													
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																													
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																													
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																													
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																													
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																													
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																													
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																													
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																													
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																													
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																													
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																													
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																													
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																													
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																													
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																													
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																													
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																													
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																													
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																													
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																													
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																														
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																														
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																														
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																														
K	2005	ALL	Chassis	ESC																																																														
K	2005	ALL	Chassis	Rear Wheel Steering																																																														
K	2005	ALL	Chassis	Tire Pressure Monitor																																																														
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																														
K	2005	ALL	Chassis	VSES																																																														
K	2005	ALL	Body	Amplifier (Bose)																																																														
K	2005	ALL	Body	Body Control Module																																																														
K	2005	ALL	Body	CD Changer																																																														
K	2005	ALL	Body	Chime																																																														
K	2005	ALL	Body	Disc Player and Video Display																																																														
K	2005	ALL	Body	Driver Door Module																																																														
K	2005	ALL	Body	Driver Seat Module																																																														
K	2005	ALL	Body	Generator Battery Control Module																																																														
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																														
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																														
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																														
K	2005	ALL	Body	Instrument Panel Cluster																																																														
K	2005	ALL	Body	Passenger Door Module																																																														
K	2005	ALL	Body	Passenger Presence System																																																														
K	2005	ALL	Body	Base Radio																																																														
K	2005	ALL	Body	Uplevel Radio																																																														
K	2005	ALL	Body	Navigation Radio																																																														
K	2005	ALL	Body	Rear Aux. Climate Module																																																														
K	2005	ALL	Body	Rear HVAC																																																														
K	2005	ALL	Body	Rear Seat Audio																																																														
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																														
K	2005	ALL	Body	Vehicle Theft Deterrent																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																														
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																														
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																														
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																														
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																													
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																														
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																														
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																														
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																														
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																														
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																														
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																														
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																														
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																														
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																														
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																														
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																														
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																														
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																														
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																														
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																														
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																														
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																														
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																														
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																														
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																														
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																														
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																														
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																														
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																														
K	2006	ALL	Chassis	ESC																																																														
K	2006	ALL	Chassis	Tire Pressure Monitor																																																														
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																														
K	2006	ALL	Chassis	VSES																																																														
K	2006	ALL	Body	Amplifier (Bose)																																																														
K	2006	ALL	Body	Body Control Module																																																														
K	2006	ALL	Body	CD Changer																																																														
K	2006	ALL	Body	Chime																																																														
K	2006	ALL	Body	Disc Player and Video Display																																																														
K	2006	ALL	Body	Driver Door Module																																																														
K	2006	ALL	Body	Driver Seat Module																																																														
K	2006	ALL	Body	Generator Battery Control Module																																																														
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																													
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																														
K	2006	ALL	Body	Instrument Panel Cluster																																																													
K	2006	ALL	Body	Passenger Door Module																																																													
K	2006	ALL	Body	Passenger Presence System																																																													
K	2006	ALL	Body	Base Radio																																																													
K	2006	ALL	Body	Uplevel Radio																																																													
K	2006	ALL	Body	Navigation Radio																																																													
K	2006	ALL	Body	Rear Aux. Climate Module																																																													
K	2006	ALL	Body	Rear HVAC																																																													
K	2006	ALL	Body	Rear Seat Audio																																																													
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																													
K	2006	ALL	Body	Vehicle Theft Deterrent																																																													
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																													
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																				
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																													
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																				
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																													
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								V																				
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																													
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																													
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																				
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																													
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																				
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																				
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																													
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																													
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																				
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																													
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																													
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																				
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																													
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																													
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																				
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																				
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																														
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																														
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																														
K	2007	Sierra	Chassis	Electronic Suspension Control																																																														
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																														
K	2007	Sierra	Body	Amplifier (Bose)																																																														
K	2007	Sierra	Body	Body Control Module																																																														
K	2007	Sierra	Body	Body Control Module (aux.)																																																														
K	2007	Sierra	Body	Digital Radio Receiver																																																														
K	2007	Sierra	Body	Driver Door Switch																																																														
K	2007	Sierra	Body	HVAC Control Module Auto																																																														
K	2007	Sierra	Body	HVAC Control Module Manual																																																														
K	2007	Sierra	Body	Instrument Panel Cluster																																																														
K	2007	Sierra	Body	Memory Seat Module																																																														
K	2007	Sierra	Body	Park Assist Module																																																														
K	2007	Sierra	Body	Passenger Door Switch																																																														
K	2007	Sierra	Body	Passenger Presence System																																																														
K	2007	Sierra	Body	Radio																																																														
K	2007	Sierra	Body	Rear Heated Seat Module																																																														
K	2007	Sierra	Body	Rear HVAC/RSA																																																														
K	2007	Sierra	Body	Rollover Sensor																																																														
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																																														
K	2007	Sierra	Body	Theft Deterrent Module																																																														
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																					
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																														
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																					
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																														
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																					
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																														
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																					
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																														
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																														
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																														
K	2007	Yukon	Chassis	Electronic Suspension Control																																																														
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																														
K	2007	Yukon	Body	Amplifier (Bose)																																																														
K	2007	Yukon	Body	Assist Step Controller																																																														
K	2007	Yukon	Body	Body Control Module																																																														
K	2007	Yukon	Body	Body Control Module (aux.)																																																														
K	2007	Yukon	Body	Digital Radio Receiver																																																														
K	2007	Yukon	Body	Driver Door Switch																																																														
K	2007	Yukon	Body	HVAC Control Module Auto																																																														
K	2007	Yukon	Body	HVAC Control Module Manual																																																														
K	2007	Yukon	Body	Instrument Panel Cluster																																																														
K	2007	Yukon	Body	Lift Gate Module																																																														
K	2007	Yukon	Body	Memory Seat Module																																																														
K	2007	Yukon	Body	Park Assist Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2007	Yukon	Body	Passenger Door Switch																																																													
K	2007	Yukon	Body	Passenger Presence System																																																														
K	2007	Yukon	Body	Radio																																																													
K	2007	Yukon	Body	Rear Heated Seat Module																																																													
K	2007	Yukon	Body	Rear HVAC/RSA																																																													
K	2007	Yukon	Body	Rollover Sensor																																																													
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																																													
K	2007	Yukon	Body	Theft Deterrent Module																																																													
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																					
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																													
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																					
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																													
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																					
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																					
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																													
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																					
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																					
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																													
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																													
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																													
K	2007	Yukon XL	Body	Amplifier (Bose)																																																													
K	2007	Yukon XL	Body	Assist Step Controller																																																													
K	2007	Yukon XL	Body	Body Control Module																																																													
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																													
K	2007	Yukon XL	Body	Digital Radio Receiver																																																													
K	2007	Yukon XL	Body	Driver Door Switch																																																													
K	2007	Yukon XL	Body	HVAC Control Module Auto																																																													
K	2007	Yukon XL	Body	HVAC Control Module Manual																																																													
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																													
K	2007	Yukon XL	Body	Lift Gate Module																																																													
K	2007	Yukon XL	Body	Memory Seat Module																																																													
K	2007	Yukon XL	Body	Park Assist Module																																																													
K	2007	Yukon XL	Body	Passenger Door Switch																																																													
K	2007	Yukon XL	Body	Passenger Presence System																																																													
K	2007	Yukon XL	Body	Radio																																																													
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																													
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																													
K	2007	Yukon XL	Body	Rollover Sensor																																																													
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																													
K	2007	Yukon XL	Body	Theft Deterrent Module																																																													
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																					

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																									V																			
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																									V																			
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																									V																			
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																									V																			
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																									V																			
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																									V																			
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																									V																			
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																									V																			
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																									V																			
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2008	Sierra	Chassis	Electronic Suspension Control																																																												
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																												
K	2008	Sierra	Body	Amplifier (Bose)																																																												
K	2008	Sierra	Body	Body Control Module																																																												
K	2008	Sierra	Body	Body Control Module (aux.)																																																												
K	2008	Sierra	Body	Digital Radio Receiver																																																												
K	2008	Sierra	Body	Driver Door Switch																																																												
K	2008	Sierra	Body	HVAC Control Module Auto																																																												
K	2008	Sierra	Body	HVAC Control Module Manual																																																												
K	2008	Sierra	Body	Instrument Panel Cluster																																																												
K	2008	Sierra	Body	Memory Seat Module																																																												
K	2008	Sierra	Body	Park Assist Module																																																												
K	2008	Sierra	Body	Passenger Door Switch																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2008	Sierra	Body	Passenger Presence System																																																													
K	2008	Sierra	Body	Radio																																																													
K	2008	Sierra	Body	Rear Heated Seat Module																																																													
K	2008	Sierra	Body	Rear HVAC/RSA																																																													
K	2008	Sierra	Body	Rollover Sensor																																																													
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																																													
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																													
K	2008	Sierra	Body	Theft Deterrent Module																																																													
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																					
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																					
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																													
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																					
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																													
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																													
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																					
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2008	Yukon	Chassis	Electronic Brake Control Module																																																													
K	2008	Yukon	Chassis	Electronic Suspension Control																																																													
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																													
K	2008	Yukon	Body	Amplifier (Bose)																																																													
K	2008	Yukon	Body	Assist Step Controller																																																													
K	2008	Yukon	Body	Body Control Module																																																													
K	2008	Yukon	Body	Body Control Module (aux.)																																																													
K	2008	Yukon	Body	Digital Radio Receiver																																																													
K	2008	Yukon	Body	Driver Door Switch																																																													
K	2008	Yukon	Body	HVAC Control Module Auto																																																													
K	2008	Yukon	Body	HVAC Control Module Manual																																																													
K	2008	Yukon	Body	Instrument Panel Cluster																																																													
K	2008	Yukon	Body	Lift Gate Module																																																													
K	2008	Yukon	Body	Memory Seat Module																																																													
K	2008	Yukon	Body	Park Assist Module																																																													
K	2008	Yukon	Body	Passenger Door Switch																																																													
K	2008	Yukon	Body	Passenger Presence System																																																													
K	2008	Yukon	Body	Radio																																																													
K	2008	Yukon	Body	Rear Heated Seat Module																																																													
K	2008	Yukon	Body	Rear HVAC/RSA																																																													
K	2008	Yukon	Body	Rollover Sensor																																																													
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																																													
K	2008	Yukon	Body	Theft Deterrent Module																																																													
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																					
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																													
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																													
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																													
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																													
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																													
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																													
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																													
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																													
K	2008	Yukon Hybrid	Body	Body Control Module																																																													
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																													
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																													
K	2008	Yukon Hybrid	Body	Driver Door Switch																																																													
K	2008	Yukon Hybrid	Body	HVAC Control Module																																																													
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																													
K	2008	Yukon Hybrid	Body	Lift Gate Module																																																													
K	2008	Yukon Hybrid	Body	Memory Seat Module																																																													
K	2008	Yukon Hybrid	Body	Park Assist Module																																																													
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																																													
K	2008	Yukon Hybrid	Body	Passenger Presence System																																																													
K	2008	Yukon Hybrid	Body	Radio																																																													
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																													
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																													
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																													
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																													
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																													
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																													
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																				
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																													
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								V																				
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																													
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																				
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								V																				
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																													
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																													
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																				
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																				
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																													
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																														
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																														
K	2008	Yukon XL	Body	Amplifier (Bose)																																																														
K	2008	Yukon XL	Body	Assist Step Controller																																																														
K	2008	Yukon XL	Body	Body Control Module																																																														
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																														
K	2008	Yukon XL	Body	Digital Radio Receiver																																																														
K	2008	Yukon XL	Body	Driver Door Switch																																																														
K	2008	Yukon XL	Body	HVAC Control Module Auto																																																														
K	2008	Yukon XL	Body	HVAC Control Module Manual																																																														
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																														
K	2008	Yukon XL	Body	Lift Gate Module																																																														
K	2008	Yukon XL	Body	Memory Seat Module																																																														
K	2008	Yukon XL	Body	Park Assist Module																																																														
K	2008	Yukon XL	Body	Passenger Door Switch																																																														
K	2008	Yukon XL	Body	Passenger Presence System																																																														
K	2008	Yukon XL	Body	Radio																																																														
K	2008	Yukon XL	Body	Rear Heated Seat Module																																																														
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																														
K	2008	Yukon XL	Body	Rollover Sensor																																																														
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																														
K	2008	Yukon XL	Body	Theft Deterrent Module																																																														
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								V																					
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																														
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																														
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																														
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								V																					
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																														
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								V																					
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																														
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																														
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																								V																					
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul																																																														
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																														
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																					
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																														
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																														
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																														
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																					
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																														
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																														
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																					
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																														
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																														
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																		
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								V																		
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																		
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2009	Sierra	Chassis	Electronic Suspension Control																																																										
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2009	Sierra	Body	Amplifier (Bose)																																																										
K	2009	Sierra	Body	Body Control Module																																																										
K	2009	Sierra	Body	Body Control Module (aux.)																																																										
K	2009	Sierra	Body	Digital Radio Receiver																																																										
K	2009	Sierra	Body	Driver Door Switch																																																										
K	2009	Sierra	Body	HVAC Control Module Auto																																																										
K	2009	Sierra	Body	HVAC Control Module Manual																																																										
K	2009	Sierra	Body	Instrument Panel Cluster																																																										
K	2009	Sierra	Body	Memory Seat Module																																																										
K	2009	Sierra	Body	Park Assist Module																																																										
K	2009	Sierra	Body	Passenger Door Switch																																																										
K	2009	Sierra	Body	Passenger Presence System																																																										
K	2009	Sierra	Body	Radio																																																										
K	2009	Sierra	Body	Rear Heated Seat Module																																																										
K	2009	Sierra	Body	Rear HVAC/RSA																																																										
K	2009	Sierra	Body	Rollover Sensor																																																										
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2009	Sierra	Body	Theft Deterrent Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								V																		
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																													
K	2009	Sierra Hybrid	Body	Body Control Module																																																													
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Sierra Hybrid	Body	Driver Door Switch																																																												
K	2009	Sierra Hybrid	Body	HVAC Control Module																																																												
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
K	2009	Sierra Hybrid	Body	Memory Seat Module																																																												
K	2009	Sierra Hybrid	Body	Park Assist Module																																																												
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																																												
K	2009	Sierra Hybrid	Body	Passenger Presence System																																																												
K	2009	Sierra Hybrid	Body	Radio																																																												
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Sierra Hybrid	Body	Rollover Sensor																																																												
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								V																			
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								V																			
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																			
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								V																			
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																			
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Yukon	Chassis	Electronic Brake Control Module																																																												
K	2009	Yukon	Chassis	Electronic Suspension Control																																																												
K	2009	Yukon	Chassis	Trailer Brake Control Module																																																												
K	2009	Yukon	Body	Amplifier (Bose)																																																												
K	2009	Yukon	Body	Assist Step Controller																																																												
K	2009	Yukon	Body	Body Control Module																																																												
K	2009	Yukon	Body	Body Control Module (aux.)																																																												
K	2009	Yukon	Body	Digital Radio Receiver																																																												
K	2009	Yukon	Body	Driver Door Switch																																																												
K	2009	Yukon	Body	HVAC Control Module Auto																																																												
K	2009	Yukon	Body	HVAC Control Module Manual																																																												

| Engine type | Year | Model | System 1 | System 2 | Hybrid/EV Battery Pack Data Reset | Brake Controls Offset Learn | Electronic Brake Control Module Learn | Battery Energy Control Module Data | Voltage Data 1 | Voltage Data 2 | Voltage Data 3 | High Voltage Contactor Lockout Status Data | Manual Service Disconnect Fuse Life Reset | BCM Data | Configuration | Electrical Data | Horn Data | Park Brake Data | Cruise Disengagement 1 | Cruise Disengagement 2 | DSCC Setup (Japan Only) | Roof History Data | Trunk History Data | Folding Top Learn Procedure | Module and Display Data | Radio Data 1 | Radio Data 2 | Door and Trunk Switches | Fob Data | Cruise Inhibit Data | Cruise Disengagement 3 | Cruise Disengagement 4 | Brake Press. Sensor Calibration | Depressurize System | Pressurize System | Induction | HVAC Data | Keyless Data | EPM Data | Cassette Data | CD Data | Automatic Transmission | Manual Transmission | Keyless Data/Remote Start Data | Auto Transmission Data | Steering Pos. Sensor Calibration | Keyless/Remote Start Data | Fuel Composition Reset | Telematic Vehicle Localization and Immobilization Data | Self-Test Data | APP Learn | Exhaust Gas Temperature Sensor Learn | MAF Sensor Learn | EGR Valve Learn | Fuel Rail Pressure Sensor or Fuel Rail Learn | Crankshaft Position Reluctor Ring Learn | Turbocharger Learn | Flywheel Learn | Glow Plug Control Module Reset | Injector Flow Rate Programming |
|---|---|---

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																													
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																									V																			
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																													
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																									V																			
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																									V																			
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																									V																			
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																													
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																									V																			
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																														
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																													
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																													
K	2009	Yukon XL	Body	Amplifier (Bose)																																																													
K	2009	Yukon XL	Body	Assist Step Controller																																																													
K	2009	Yukon XL	Body	Body Control Module																																																													
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																													
K	2009	Yukon XL	Body	Digital Radio Receiver																																																													
K	2009	Yukon XL	Body	Driver Door Switch																																																													
K	2009	Yukon XL	Body	HVAC Control Module Auto																																																													
K	2009	Yukon XL	Body	HVAC Control Module Manual																																																													
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																													
K	2009	Yukon XL	Body	Left Side Object Detection Module																																																													
K	2009	Yukon XL	Body	Lift Gate Module																																																													
K	2009	Yukon XL	Body	Memory Seat Module																																																													
K	2009	Yukon XL	Body	Park Assist Module																																																													
K	2009	Yukon XL	Body	Passenger Door Switch																																																													
K	2009	Yukon XL	Body	Passenger Presence System																																																													
K	2009	Yukon XL	Body	Radio																																																													
K	2009	Yukon XL	Body	Rear Heated Seat Module																																																													
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																													
K	2009	Yukon XL	Body	Right Side Object Detection Module																																																													
K	2009	Yukon XL	Body	Rollover Sensor																																																													
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																													
K	2009	Yukon XL	Body	Theft Deterrent Module																																																													
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																													
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																													
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																															
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																															
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																															
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																															
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																															
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																															
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																															
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V																						
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																															
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																															
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																															
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																															
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																						
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																															
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																															
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																						
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																															
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																															
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																															
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																															
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																															
K	2010	Sierra	Chassis	Electronic Suspension Control																																																															
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																															
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																															
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																															
K	2010	Sierra	Body	Amplifier (Bose)																																																															
K	2010	Sierra	Body	Body Control Module																																																															
K	2010	Sierra	Body	Body Control Module (aux.)																																																															
K	2010	Sierra	Body	Digital Radio Receiver																																																															
K	2010	Sierra	Body	Driver Door Switch																																																															
K	2010	Sierra	Body	HVAC Control Module Auto																																																															
K	2010	Sierra	Body	HVAC Control Module Manual																																																															
K	2010	Sierra	Body	Instrument Panel Cluster																																																															
K	2010	Sierra	Body	Memory Seat Module																																																															
K	2010	Sierra	Body	Park Assist Module																																																															
K	2010	Sierra	Body	Passenger Door Switch																																																															
K	2010	Sierra	Body	Passenger Presence System																																																															
K	2010	Sierra	Body	Radio																																																															
K	2010	Sierra	Body	Rear Heated Seat Module																																																															
K	2010	Sierra	Body	Rear HVAC/RSA																																																															
K	2010	Sierra	Body	Supplemental Inflatable Restraint																																																															
K	2010	Sierra	Body	Theft Deterrent Module																																																															
K	2010	Sierra Hybrid	Powertrain	Engine Control Module																																								V																						
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																														
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																														
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																														
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																														
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																														
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																														
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																														
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																														
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																														
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																														
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																														
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																														
K	2010	Sierra Hybrid	Body	Body Control Module																																																														
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																														
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																														
K	2010	Sierra Hybrid	Body	Driver Door Switch																																																														
K	2010	Sierra Hybrid	Body	Heated Seat Module																																																														
K	2010	Sierra Hybrid	Body	HVAC Control Module																																																														
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																														
K	2010	Sierra Hybrid	Body	Park Assist Module																																																														
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																																														
K	2010	Sierra Hybrid	Body	Passenger Presence System																																																														
K	2010	Sierra Hybrid	Body	Radio																																																														
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																														
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																														
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																														
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																														
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																														
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								V																					
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																														
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																														
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								V																					
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																														
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																														
K	2010	Yukon	Chassis	Electronic Brake Control Module																																																														
K	2010	Yukon	Chassis	Electronic Suspension Control																																																														
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																														
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																														
K	2010	Yukon	Body	Amplifier (Bose)																																																														
K	2010	Yukon	Body	Assist Step Controller																																																														
K	2010	Yukon	Body	Body Control Module																																																														
K	2010	Yukon	Body	Body Control Module (aux.)																																																														
K	2010	Yukon	Body	Digital Radio Receiver																																																														
K	2010	Yukon	Body	Driver Door Switch																																																														
K	2010	Yukon	Body	HVAC Control Module Auto																																																														
K	2010	Yukon	Body	HVAC Control Module Manual																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2010	Yukon	Body	Instrument Panel Cluster																																																															
K	2010	Yukon	Body	Left Side Object Detection Module																																																															
K	2010	Yukon	Body	Lift Gate Module																																																															
K	2010	Yukon	Body	Memory Seat Module																																																															
K	2010	Yukon	Body	Park Assist Module																																																															
K	2010	Yukon	Body	Passenger Door Switch																																																															
K	2010	Yukon	Body	Passenger Presence System																																																															
K	2010	Yukon	Body	Radio																																																															
K	2010	Yukon	Body	Rear Heated Seat Module																																																															
K	2010	Yukon	Body	Rear HVAC/RSA																																																															
K	2010	Yukon	Body	Right Side Object Detection Module																																																															
K	2010	Yukon	Body	Supplemental Inflatable Restraint																																																															
K	2010	Yukon	Body	Theft Deterrent Module																																																															
K	2010	Yukon Hybrid	Powertrain	Engine Control Module																																								V																						
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																															
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																															
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																															
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																															
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																															
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																															
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																															
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																															
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																															
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																															
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																															
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																															
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																															
K	2010	Yukon Hybrid	Body	Body Control Module																																																															
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																															
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																															
K	2010	Yukon Hybrid	Body	Driver Door Switch																																																															
K	2010	Yukon Hybrid	Body	Heated Seat Module																																																															
K	2010	Yukon Hybrid	Body	HVAC Control Module																																																															
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																															
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																															
K	2010	Yukon Hybrid	Body	Lift Gate Module																																																															
K	2010	Yukon Hybrid	Body	Park Assist Module																																																															
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																																															
K	2010	Yukon Hybrid	Body	Passenger Presence System																																																															
K	2010	Yukon Hybrid	Body	Radio																																																															
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																															
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																															
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																															
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																															
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																															
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																															
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																															
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								V																			
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								V																			
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																												
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																												
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																												
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																												
K	2010	Yukon XL	Body	Amplifier (Bose)																																																												
K	2010	Yukon XL	Body	Assist Step Controller																																																												
K	2010	Yukon XL	Body	Body Control Module																																																												
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																												
K	2010	Yukon XL	Body	Digital Radio Receiver																																																												
K	2010	Yukon XL	Body	Driver Door Switch																																																												
K	2010	Yukon XL	Body	HVAC Control Module Auto																																																												
K	2010	Yukon XL	Body	HVAC Control Module Manual																																																												
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																												
K	2010	Yukon XL	Body	Left Side Object Detection Module																																																												
K	2010	Yukon XL	Body	Lift Gate Module																																																												
K	2010	Yukon XL	Body	Memory Seat Module																																																												
K	2010	Yukon XL	Body	Park Assist Module																																																												
K	2010	Yukon XL	Body	Passenger Door Switch																																																												
K	2010	Yukon XL	Body	Passenger Presence System																																																												
K	2010	Yukon XL	Body	Radio																																																												
K	2010	Yukon XL	Body	Rear Heated Seat Module																																																												
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																												
K	2010	Yukon XL	Body	Right Side Object Detection Module																																																												
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
K	2010	Yukon XL	Body	Theft Deterrent Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
L	2004	ALL	Chassis	4WAL 3 Sensor																																																												
L	2004	ALL	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2004	ALL	Body	Instrument Panel Cluster																																																														
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																														
L	2005	ALL	Chassis	4WAL 3 Sensor																																																														
L	2005	ALL	Body	Body Control Module																																																														
L	2005	ALL	Body	Instrument Panel Cluster																																																														
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																														
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																														
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																														
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																														
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																														
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																														
L	2010	Terrain	Chassis	Electronic Brake Control Module																																																														
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2010	Terrain	Body	Body Control Module																																																														
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2010	Terrain	Body	Passenger Presence Module																																																														
L	2010	Terrain	Body	Instrument Cluster																																																														
L	2010	Terrain	Body	Radio																																																														
L	2010	Terrain	Body	Multimedia Player Interface Module																																																														
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																																														
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																														
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																														
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																																														
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																																														
L	2010	Terrain	Body	Liftgate Control Module																																																														
L	2010	Terrain	Body	Parking Assist Control Module																																																														
L	2010	Terrain	Body	Frontview Camera Module																																																														
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																																														
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																																														
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																														
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																														
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																														
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																														
L	2011	Terrain	Chassis	Electronic Brake Control Module																																																														
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2011	Terrain	Body	Body Control Module																																																														
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2011	Terrain	Body	Passenger Presence Module																																																														
L	2011	Terrain	Body	Instrument Cluster																																																														
L	2011	Terrain	Body	Radio																																																														
L	2011	Terrain	Body	Multimedia Player Interface Module																																																														
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																														
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																														
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																																														
L	2011	Terrain	Body	Liftgate Control Module																																																														
L	2011	Terrain	Body	Parking Assist Control Module																																																														
L	2011	Terrain	Body	Frontview Camera Module																																																														
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																																														
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																														
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																														
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																														
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																														
L	2012	Terrain	Chassis	Electronic Brake Control Module																																																														
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2012	Terrain	Body	Body Control Module																																																														
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2012	Terrain	Body	Passenger Presence Module																																																														
L	2012	Terrain	Body	Instrument Cluster																																																														
L	2012	Terrain	Body	Radio																																																														
L	2012	Terrain	Body	Multimedia Player Interface Module																																																														
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																														
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																														
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																																														
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																																														
L	2012	Terrain	Body	Liftgate Control Module																																																														
L	2012	Terrain	Body	Parking Assist Control Module																																																														
L	2012	Terrain	Body	Frontview Camera Module																																																														
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																																														
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																														
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																														
L	2013	Terrain	Chassis	Electronic Brake Control Module																																																														
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2013	Terrain	Chassis	Power Steering Control Module																																																														
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																																														
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																														
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2013	Terrain	Body	Passenger Presence Module																																																														
L	2013	Terrain	Body	Instrument Cluster																																																														
L	2013	Terrain	Body	Radio																																																														
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																														
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																														
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																																														
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																																														
L	2013	Terrain	Body	Liftgate Control Module																																																														
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																														
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																														
L	2013	Terrain	Body	Parking Assist Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2013	Terrain	Body	Frontview Camera Module																																																														
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																														
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																														
L	2014	Terrain	Chassis	Electronic Brake Control Module																																																														
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2014	Terrain	Chassis	Power Steering Control Module																																																														
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																																														
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																														
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2014	Terrain	Body	Passenger Presence Module																																																														
L	2014	Terrain	Body	Instrument Cluster																																																														
L	2014	Terrain	Body	Radio																																																														
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																														
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																														
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																																														
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																																														
L	2014	Terrain	Body	Liftgate Control Module																																																														
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																														
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																														
L	2014	Terrain	Body	Parking Assist Control Module																																																														
L	2014	Terrain	Body	Frontview Camera Module																																																														
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																														
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																														
L	2015	Terrain	Chassis	Electronic Brake Control Module																																																														
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2015	Terrain	Chassis	Power Steering Control Module																																																														
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																																													
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																													
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
L	2015	Terrain	Body	Passenger Presence Module																																																														
L	2015	Terrain	Body	Instrument Cluster																																																														
L	2015	Terrain	Body	Radio																																																														
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																																														
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																																														
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																																														
L	2015	Terrain	Body	Liftgate Control Module																																																														
L	2015	Terrain	Body	Seat Memory Control Module																																																														
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																														
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																														
L	2015	Terrain	Body	Parking Assist Control Module																																																														
L	2015	Terrain	Body	Frontview Camera Module																																																														
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																														
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																														
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																														
L	2016	Terrain	Chassis	Electronic Brake Control Module																																																														
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2016	Terrain	Chassis	Power Steering Control Module																																																														
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																																														
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																														
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2016	Terrain	Body	Passenger Presence Module																																																														
L	2016	Terrain	Body	Instrument Cluster																																																														
L	2016	Terrain	Body	Radio																																																														
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																																														
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																														
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																																														
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																																														
L	2016	Terrain	Body	Liftgate Control Module																																																														
L	2016	Terrain	Body	Seat Memory Control Module																																																														
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																														
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																														
L	2016	Terrain	Body	Parking Assist Control Module																																																														
L	2016	Terrain	Body	Frontview Camera Module																																																														
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
M	2004	ALL	Chassis	4WAL 3 Sensor																																																														
M	2004	ALL	Body	Body Control Module																																																														
M	2004	ALL	Body	Instrument Panel Cluster																																																														
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
M	2005	ALL	Chassis	4WAL 3 Sensor																																																														
M	2005	ALL	Body	Body Control Module																																																														
M	2005	ALL	Body	Instrument Panel Cluster																																																														
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																														
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																														
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																														
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																														
P	2007	ALL	Body	Theft Deterrent Module																																																														
R	2007	ALL	Powertrain	Engine Control Module																																																														
R	2007	ALL	Powertrain	Transmission Control Module																																																														
R	2007	ALL	Chassis	Electronic Brake Control Module																																																														
R	2007	ALL	Body	Body Control Module																																																														
R	2007	ALL	Body	Digital Radio Receiver																																																														
R	2007	ALL	Body	Driver Door Switch																																																														
R	2007	ALL	Body	Head Up Display																																																														
R	2007	ALL	Body	Heated Seat Module																																																														
R	2007	ALL	Body	HVAC Control Module Auto																																																														
R	2007	ALL	Body	HVAC Control Module Manual																																																														
R	2007	ALL	Body	Instrument Panel Cluster																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2007	ALL	Body	Lift Gate Module																																																															
R	2007	ALL	Body	Park Assist Module																																																															
R	2007	ALL	Body	Passenger Door Switch																																																															
R	2007	ALL	Body	Passenger Presence System																																																															
R	2007	ALL	Body	Radio																																																															
R	2007	ALL	Body	Rear HVAC/RSA																																																															
R	2007	ALL	Body	Rollover Sensor																																																															
R	2007	ALL	Body	Supplemental Inflatable Restraint																																																															
R	2007	ALL	Body	Theft Deterrent Module																																																															
R	2008	ALL	Powertrain	Engine Control Module																																																															
R	2008	ALL	Powertrain	Transmission Control Module																																																															
R	2008	ALL	Chassis	Electronic Brake Control Module																																																															
R	2008	ALL	Body	Body Control Module																																																															
R	2008	ALL	Body	Digital Radio Receiver																																																															
R	2008	ALL	Body	Driver Door Switch																																																															
R	2008	ALL	Body	Head Up Display																																																															
R	2008	ALL	Body	Heated Seat Module																																																															
R	2008	ALL	Body	HVAC Control Module Auto																																																															
R	2008	ALL	Body	HVAC Control Module Manual																																																															
R	2008	ALL	Body	Instrument Panel Cluster																																																															
R	2008	ALL	Body	Lift Gate Module																																																															
R	2008	ALL	Body	Park Assist Module																																																															
R	2008	ALL	Body	Passenger Door Switch																																																															
R	2008	ALL	Body	Passenger Presence System																																																															
R	2008	ALL	Body	Radio																																																															
R	2008	ALL	Body	Rear HVAC/RSA																																																															
R	2008	ALL	Body	Rollover Sensor																																																															
R	2008	ALL	Body	Supplemental Inflatable Restraint																																																															
R	2008	ALL	Body	Theft Deterrent Module																																																															
R	2009	ALL	Powertrain	Engine Control Module																																																															
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																															
R	2009	ALL	Powertrain	Transmission Control Module																																																															
R	2009	ALL	Chassis	Electronic Brake Control Module																																																															
R	2009	ALL	Body	Body Control Module																																																															
R	2009	ALL	Body	Digital Radio Receiver																																																															
R	2009	ALL	Body	Driver Door Switch																																																															
R	2009	ALL	Body	Head Up Display																																																															
R	2009	ALL	Body	Heated Seat Module																																																															
R	2009	ALL	Body	HVAC Control Module Auto																																																															
R	2009	ALL	Body	HVAC Control Module Manual																																																															
R	2009	ALL	Body	Instrument Panel Cluster																																																															
R	2009	ALL	Body	Lift Gate Module																																																															
R	2009	ALL	Body	Park Assist Module																																																															
R	2009	ALL	Body	Passenger Door Switch																																																															
R	2009	ALL	Body	Passenger Presence System																																																															
R	2009	ALL	Body	Radio																																																															
R	2009	ALL	Body	Rear HVAC/RSA																																																															
R	2009	ALL	Body	Rollover Sensor																																																															
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																															
R	2009	ALL	Body	Theft Deterrent Module																																																															
R	2010	ALL	Powertrain	Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																														
R	2010	ALL	Powertrain	Transmission Control Module																																																														
R	2010	ALL	Chassis	Electronic Brake Control Module																																																														
R	2010	ALL	Body	Body Control Module																																																														
R	2010	ALL	Body	Digital Radio Receiver																																																														
R	2010	ALL	Body	Driver Door Switch																																																														
R	2010	ALL	Body	Head Up Display																																																														
R	2010	ALL	Body	Heated Seat Module																																																														
R	2010	ALL	Body	HVAC Control Module Auto																																																														
R	2010	ALL	Body	HVAC Control Module Manual																																																														
R	2010	ALL	Body	Instrument Panel Cluster																																																														
R	2010	ALL	Body	Lift Gate Module																																																														
R	2010	ALL	Body	Park Assist Module																																																														
R	2010	ALL	Body	Passenger Door Switch																																																														
R	2010	ALL	Body	Passenger Presence System																																																														
R	2010	ALL	Body	Radio																																																														
R	2010	ALL	Body	Rear HVAC/RSA																																																														
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																														
R	2010	ALL	Body	Theft Deterrent Module																																																														
R	2011	ALL	Powertrain	Engine Control Module																																																															
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																															
R	2011	ALL	Powertrain	Transmission Control Module																																																															
R	2011	ALL	Chassis	Electronic Brake Control Module																																																															
R	2011	ALL	Body	Body Control Module																																																															
R	2011	ALL	Body	Digital Radio Receiver																																																															
R	2011	ALL	Body	Driver Door Switch																																																															
R	2011	ALL	Body	Head Up Display																																																															
R	2011	ALL	Body	Heated Seat Module																																																															
R	2011	ALL	Body	HVAC Control Module Auto																																																															
R	2011	ALL	Body	HVAC Control Module Manual																																																															
R	2011	ALL	Body	Instrument Panel Cluster																																																															
R	2011	ALL	Body	Lift Gate Module																																																															
R	2011	ALL	Body	Park Assist Module																																																															
R	2011	ALL	Body	Passenger Door Switch																																																															
R	2011	ALL	Body	Passenger Presence System																																																															
R	2011	ALL	Body	Radio																																																															
R	2011	ALL	Body	Rear HVAC/RSA																																																															
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																															
R	2011	ALL	Body	Theft Deterrent Module																																																															
R	2012	ALL	Powertrain	Engine Control Module																																																															
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																															
R	2012	ALL	Powertrain	Transmission Control Module																																																															
R	2012	ALL	Chassis	Electronic Brake Control Module																																																															
R	2012	ALL	Body	Body Control Module																																																															
R	2012	ALL	Body	Digital Radio Receiver																																																															
R	2012	ALL	Body	Driver Door Switch																																																															
R	2012	ALL	Body	Head Up Display																																																															
R	2012	ALL	Body	Heated Seat Module																																																															
R	2012	ALL	Body	HVAC Control Module Auto																																																															
R	2012	ALL	Body	HVAC Control Module Manual																																																															
R	2012	ALL	Body	Instrument Panel Cluster																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2012	ALL	Body	Lift Gate Module																																																															
R	2012	ALL	Body	Park Assist Module																																																																
R	2012	ALL	Body	Passenger Door Switch																																																																
R	2012	ALL	Body	Passenger Presence System																																																																
R	2012	ALL	Body	Radio																																																																
R	2012	ALL	Body	Rear HVAC/RSA																																																																
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																																
R	2012	ALL	Body	Theft Deterrent Module																																																																
R	2013	ALL	Powertrain	Engine Control Module																																																																
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																																
R	2013	ALL	Powertrain	Transmission Control Module																																																																
R	2013	ALL	Chassis	Electronic Brake Control Module																																																																
R	2013	ALL	Body	Body Control Module																																																																
R	2013	ALL	Body	Digital Radio Receiver																																																																
R	2013	ALL	Body	Driver Door Switch																																																																
R	2013	ALL	Body	Head Up Display																																																																
R	2013	ALL	Body	Heated Seat Module																																																																
R	2013	ALL	Body	HVAC Control Module Auto																																																																
R	2013	ALL	Body	HVAC Control Module Manual																																																																
R	2013	ALL	Body	Instrument Panel Cluster																																																																
R	2013	ALL	Body	Left Side Object Detection Module																																																																
R	2013	ALL	Body	Lift Gate Module																																																																
R	2013	ALL	Body	Park Assist Module																																																																
R	2013	ALL	Body	Passenger Door Switch																																																																
R	2013	ALL	Body	Passenger Presence System																																																																
R	2013	ALL	Body	Radio																																																																
R	2013	ALL	Body	Rear HVAC/RSA																																																																
R	2013	ALL	Body	Right Side Object Detection Module																																																																
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																																
R	2013	ALL	Body	Theft Deterrent Module																																																																
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																																
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																																
R	2014	Acadia	Powertrain	Chassis Control Module																																																																
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																																
R	2014	Acadia	Chassis	Electronic Brake Control Module																																																																
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																																
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																																
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
R	2014	Acadia	Body	Passenger Presence Module																																																																
R	2014	Acadia	Body	Instrument Cluster																																																																
R	2014	Acadia	Body	Head-Up Display Module																																																																
R	2014	Acadia	Body	Radio																																																																
R	2014	Acadia	Body	Rear Audio Control Module																																																																
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																																
R	2014	Acadia	Body	Personal Audio Link Control Module																																																																
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																																
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																																
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																																
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																																
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																																
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																																

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2014	Acadia	Body	Liftgate Control Module																																																														
R	2014	Acadia	Body	Seat Memory Control Module																																																														
R	2014	Acadia	Body	Front Seat Heating Control Module																																																														
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																														
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																														
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																														
R	2014	Acadia	Body	Parking Assist Control Module																																																														
R	2014	Acadia	Body	Frontview Camera Module																																																														
R	2014	Acadia	Body	Theft Deterrent Module																																																														
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																														
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																														
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																														
R	2015	Acadia	Chassis	Electronic Brake Control Module																																																														
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																														
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																														
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
R	2015	Acadia	Body	Passenger Presence Module																																																														
R	2015	Acadia	Body	Instrument Cluster																																																															
R	2015	Acadia	Body	Head-Up Display Module																																																															
R	2015	Acadia	Body	Radio																																																														
R	2015	Acadia	Body	Rear Audio Control Module																																																														
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																														
R	2015	Acadia	Body	Personal Audio Link Control Module																																																														
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																														
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																														
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																														
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																														
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																														
R	2015	Acadia	Body	Liftgate Control Module																																																															
R	2015	Acadia	Body	Seat Memory Control Module																																																															
R	2015	Acadia	Body	Front Seat Heating Control Module																																																															
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																															
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																															
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																															
R	2015	Acadia	Body	Parking Assist Control Module																																																															
R	2015	Acadia	Body	Frontview Camera Module																																																															
R	2015	Acadia	Body	Theft Deterrent Module																																																															
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																															
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																															
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																															
R	2016	Acadia	Chassis	Electronic Brake Control Module																																																															
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																															
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																														
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
R	2016	Acadia	Body	Passenger Presence Module																																																															
R	2016	Acadia	Body	Instrument Cluster																																																															
R	2016	Acadia	Body	Head-Up Display Module																																																															
R	2016	Acadia	Body	Radio																																																														
R	2016	Acadia	Body	Rear Audio Control Module																																																														
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
R	2016	Acadia	Body	Personal Audio Link Control Module																																																														
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																														
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																														
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																													
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																													
R	2016	Acadia	Body	Liftgate Control Module																																																													
R	2016	Acadia	Body	Seat Memory Control Module																																																													
R	2016	Acadia	Body	Front Seat Heating Control Module																																																													
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																													
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																													
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																													
R	2016	Acadia	Body	Parking Assist Control Module																																																													
R	2016	Acadia	Body	Frontview Camera Module																																																													
R	2016	Acadia	Body	Theft Deterrent Module																																																													
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																													
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																													
S	2004	Sonoma	Body	Body Control Module																																																													
S	2004	Sonoma	Body	Instrument Panel Cluster																																																													
S	2004	Sonoma	Body	Base Radio																																																													
S	2004	Sonoma	Body	Uplevel Radio																																																													
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																													
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																													
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																													
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																													
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																													
S	2004	Canyon	Chassis	ABS Without Traction Control																																																													
S	2004	Canyon	Chassis	ABS With Traction Control																																																													
S	2004	Canyon	Body	Body Control Module																																																													
S	2004	Canyon	Body	Instrument Panel Cluster																																																													
S	2004	Canyon	Body	OnStar																																																													
S	2004	Canyon	Body	Base Radio																																																													
S	2004	Canyon	Body	Uplevel Radio																																																													
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																																													
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
S	2004	Envoy	Chassis	ABS Without Traction Control																																																													
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																													
S	2004	Envoy	Body	Amplifier (Bose)																																																													
S	2004	Envoy	Body	Body Control Module																																																													
S	2004	Envoy	Body	Driver Door Module																																																													
S	2004	Envoy	Body	Driver Seat Module																																																													
S	2004	Envoy	Body	Heating and Air Conditioning Auto																																																													
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																													
S	2004	Envoy	Body	Instrument Panel Cluster																																																													
S	2004	Envoy	Body	Lift Gate Module																																																													
S	2004	Envoy	Body	OnStar																																																													
S	2004	Envoy	Body	Passenger Door Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2004	Envoy	Body	Uplevel Radio																																																															
S	2004	Envoy	Body	Navigation Radio																																																															
S	2004	Envoy	Body	Rear Seat Audio																																																															
S	2004	Envoy	Body	Rear Seat Entertainment																																																															
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																																															
S	2004	Envoy	Body	Vehicle Theft Deterrent																																																															
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																															
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																															
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																															
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																															
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																															
S	2004	Envoy XL	Body	Amplifier (Bose)																																																															
S	2004	Envoy XL	Body	Body Control Module																																																															
S	2004	Envoy XL	Body	Driver Door Module																																																															
S	2004	Envoy XL	Body	Driver Seat Module																																																															
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																															
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																															
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																															
S	2004	Envoy XL	Body	Lift Gate Module																																																															
S	2004	Envoy XL	Body	OnStar																																																															
S	2004	Envoy XL	Body	Passenger Door Module																																																															
S	2004	Envoy XL	Body	Uplevel Radio																																																															
S	2004	Envoy XL	Body	Navigation Radio																																																															
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																															
S	2004	Envoy XL	Body	Rear HVAC Manual																																																															
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																															
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																															
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																															
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																															
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																															
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																															
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																															
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																															
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																															
S	2004	Envoy XUV	Body	Body Control Module																																																															
S	2004	Envoy XUV	Body	Driver Door Module																																																															
S	2004	Envoy XUV	Body	Driver Seat Module																																																															
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																															
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																															
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																															
S	2004	Envoy XUV	Body	Lift Gate Module																																																															
S	2004	Envoy XUV	Body	OnStar																																																															
S	2004	Envoy XUV	Body	Passenger Door Module																																																															
S	2004	Envoy XUV	Body	Uplevel Radio																																																															
S	2004	Envoy XUV	Body	Navigation Radio																																																															
S	2004	Envoy XUV	Body	Rear Seat Audio																																																															
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																										
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Jimmy	Body	Body Control Module																																																										
S	2004	Jimmy	Body	Heating and Air Conditioning																																																										
S	2004	Jimmy	Body	Instrument Panel Cluster																																																										
S	2004	Jimmy	Body	Memory Seat Module																																																										
S	2004	Jimmy	Body	Base Radio																																																										
S	2004	Jimmy	Body	Uplevel Radio																																																										
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2005	Canyon	Chassis	ABS Without Traction Control																																																										
S	2005	Canyon	Chassis	ABS With Traction Control																																																										
S	2005	Canyon	Body	Body Control Module																																																										
S	2005	Canyon	Body	Instrument Panel Cluster																																																										
S	2005	Canyon	Body	Base Radio																																																										
S	2005	Canyon	Body	Uplevel Radio																																																										
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																					V																					
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy	Body	Body Control Module																																																										
S	2005	Envoy	Body	Disc Player and Video Display																																																										
S	2005	Envoy	Body	Driver Door Module																																																										
S	2005	Envoy	Body	Driver Seat Module																																																										
S	2005	Envoy	Body	Heating and Air Conditioning Auto																																																										
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy	Body	Instrument Panel Cluster																																																										
S	2005	Envoy	Body	Lift Gate Module																																																										
S	2005	Envoy	Body	Passenger Door Module																																																										
S	2005	Envoy	Body	Passenger Presence System																																																										
S	2005	Envoy	Body	Uplevel Radio																																																										
S	2005	Envoy	Body	Navigation Radio																																																										
S	2005	Envoy	Body	Rear Seat Audio																																																										
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																					V																					

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																														
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																														
S	2005	Envoy XL	Body	Body Control Module																																																														
S	2005	Envoy XL	Body	Disc Player and Video Display																																																														
S	2005	Envoy XL	Body	Driver Door Module																																																														
S	2005	Envoy XL	Body	Driver Seat Module																																																														
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																														
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																														
S	2005	Envoy XL	Body	Instrument Panel Cluster																																																														
S	2005	Envoy XL	Body	Lift Gate Module																																																														
S	2005	Envoy XL	Body	Passenger Door Module																																																														
S	2005	Envoy XL	Body	Passenger Presence System																																																														
S	2005	Envoy XL	Body	Uplevel Radio																																																														
S	2005	Envoy XL	Body	Navigation Radio																																																														
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																														
S	2005	Envoy XL	Body	Rear HVAC Manual																																																														
S	2005	Envoy XL	Body	Rear Seat Audio																																																														
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																														
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																														
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																														
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																						V																								
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																														
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																														
S	2005	Envoy XUV	Body	Body Control Module																																																														
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																														
S	2005	Envoy XUV	Body	Driver Door Module																																																														
S	2005	Envoy XUV	Body	Driver Seat Module																																																														
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																														
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																														
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																																														
S	2005	Envoy XUV	Body	Lift Gate Module																																																														
S	2005	Envoy XUV	Body	Passenger Door Module																																																														
S	2005	Envoy XUV	Body	Passenger Presence System																																																														
S	2005	Envoy XUV	Body	Uplevel Radio																																																														
S	2005	Envoy XUV	Body	Navigation Radio																																																														
S	2005	Envoy XUV	Body	Rear Seat Audio																																																														
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																														
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																														
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																														
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																														
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																														
S	2005	Jimmy	Body	Body Control Module																																																														
S	2005	Jimmy	Body	Heating and Air Conditioning																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2005	Jimmy	Body	Instrument Panel Cluster																																																														
S	2005	Jimmy	Body	Memory Seat Module																																																														
S	2005	Jimmy	Body	Base Radio																																																														
S	2005	Jimmy	Body	Uplevel Radio																																																														
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																														
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																														
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																														
S	2005	Sonoma	Body	Body Control Module																																																														
S	2005	Sonoma	Body	Instrument Panel Cluster																																																														
S	2005	Sonoma	Body	Base Radio																																																														
S	2005	Sonoma	Body	Uplevel Radio																																																														
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																														
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																														
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																														
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																														
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																														
S	2006	Canyon	Chassis	ABS Without Traction Control																																																														
S	2006	Canyon	Chassis	ABS With Traction Control																																																														
S	2006	Canyon	Body	Body Control Module																																																														
S	2006	Canyon	Body	Instrument Panel Cluster																																																														
S	2006	Canyon	Body	Passenger Presence System																																																														
S	2006	Canyon	Body	Base Radio																																																														
S	2006	Canyon	Body	Uplevel Radio																																																														
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																																														
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																																														
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																						V																						
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																						V																						
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
S	2006	Envoy	Chassis	ABS/TCS/VSES																																																														
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																														
S	2006	Envoy	Body	Body Control Module																																																														
S	2006	Envoy	Body	Disc Player and Video Display																																																														
S	2006	Envoy	Body	Driver Door Module																																																														
S	2006	Envoy	Body	Driver Seat Module																																																														
S	2006	Envoy	Body	Heating and Air Conditioning Auto																																																														
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																																														
S	2006	Envoy	Body	Instrument Panel Cluster																																																														
S	2006	Envoy	Body	Lift Gate Module																																																														
S	2006	Envoy	Body	Passenger Door Module																																																														
S	2006	Envoy	Body	Passenger Presence System																																																														
S	2006	Envoy	Body	Uplevel Radio																																																														
S	2006	Envoy	Body	Navigation Radio																																																														
S	2006	Envoy	Body	Rear Seat Audio																																																														
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																																														
S	2006	Envoy	Body	Vehicle Theft Deterrent																																																														
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																						V																							
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																												
S	2006	Envoy XL	Body	Body Control Module																																																												
S	2006	Envoy XL	Body	Disc Player and Video Display																																																												
S	2006	Envoy XL	Body	Driver Door Module																																																												
S	2006	Envoy XL	Body	Driver Seat Module																																																												
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
S	2006	Envoy XL	Body	Instrument Panel Cluster																																																												
S	2006	Envoy XL	Body	Lift Gate Module																																																												
S	2006	Envoy XL	Body	Passenger Door Module																																																												
S	2006	Envoy XL	Body	Passenger Presence System																																																												
S	2006	Envoy XL	Body	Uplevel Radio																																																												
S	2006	Envoy XL	Body	Navigation Radio																																																												
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
S	2006	Envoy XL	Body	Rear HVAC Manual																																																												
S	2006	Envoy XL	Body	Rear Seat Audio																																																												
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																												
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																												
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																V																													
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																V																													
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2007	Canyon	Body	Body Control Module																																																												
S	2007	Canyon	Body	Digital Radio Receiver																																																												
S	2007	Canyon	Body	Generator Battery Control Module																																																												
S	2007	Canyon	Body	Instrument Panel Cluster																																																												
S	2007	Canyon	Body	Passenger Presence System																																																												
S	2007	Canyon	Body	Base Radio																																																												
S	2007	Canyon	Body	Uplevel Radio																																																												
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																																												
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																																												
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																V																													
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																V																													
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																												
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2007	Envoy	Chassis	Electronic Brake Control Module																																																												
S	2007	Envoy	Body	Body Control Module																																																												
S	2007	Envoy	Body	Digital Radio Receiver																																																												
S	2007	Envoy	Body	Disc Player and Video Display																																																												
S	2007	Envoy	Body	Driver Door Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2007	Envoy	Body	Driver Seat Module																																																														
S	2007	Envoy	Body	Generator Battery Control Module																																																														
S	2007	Envoy	Body	HVAC Control Module Auto																																																														
S	2007	Envoy	Body	HVAC Control Module Manual																																																														
S	2007	Envoy	Body	Instrument Panel Cluster																																																														
S	2007	Envoy	Body	Lift Gate Module																																																														
S	2007	Envoy	Body	Passenger Door Module																																																														
S	2007	Envoy	Body	Passenger Presence System																																																														
S	2007	Envoy	Body	Uplevel Radio																																																														
S	2007	Envoy	Body	Navigation Radio																																																														
S	2007	Envoy	Body	Rear Seat Audio																																																														
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																																														
S	2007	Envoy	Body	Theft Deterrent Module																																																														
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																																														
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																														
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																														
S	2008	Canyon	Body	Body Control Module																																																														
S	2008	Canyon	Body	Digital Radio Receiver																																																														
S	2008	Canyon	Body	Generator Battery Control Module																																																														
S	2008	Canyon	Body	Instrument Panel Cluster																																																														
S	2008	Canyon	Body	Passenger Presence System																																																														
S	2008	Canyon	Body	Base Radio																																																														
S	2008	Canyon	Body	Uplevel Radio																																																														
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																																														
S	2008	Canyon	Body	Theft Deterrent Module																																																														
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																																														
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																														
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
S	2008	Envoy	Chassis	Electronic Brake Control Module																																																														
S	2008	Envoy	Body	Body Control Module																																																														
S	2008	Envoy	Body	Digital Radio Receiver																																																														
S	2008	Envoy	Body	Disc Player and Video Display																																																														
S	2008	Envoy	Body	Driver Door Module																																																														
S	2008	Envoy	Body	Driver Seat Module																																																														
S	2008	Envoy	Body	Generator Battery Control Module																																																														
S	2008	Envoy	Body	HVAC Control Module Auto																																																														
S	2008	Envoy	Body	HVAC Control Module Manual																																																														
S	2008	Envoy	Body	Instrument Panel Cluster																																																														
S	2008	Envoy	Body	Lift Gate Module																																																														
S	2008	Envoy	Body	Passenger Door Module																																																														
S	2008	Envoy	Body	Passenger Presence System																																																														
S	2008	Envoy	Body	Uplevel Radio																																																														
S	2008	Envoy	Body	Navigation Radio																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2008	Envoy	Body	Rear Seat Audio																																																														
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																																														
S	2008	Envoy	Body	Theft Deterrent Module																																																														
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																																														
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																														
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																														
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																														
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																														
S	2009	Canyon	Chassis	Electronic Brake Control Module																																																															
S	2009	Canyon	Body	Body Control Module																																																															
S	2009	Canyon	Body	Digital Radio Receiver																																																															
S	2009	Canyon	Body	Generator Battery Control Module																																																															
S	2009	Canyon	Body	Instrument Panel Cluster																																																															
S	2009	Canyon	Body	Passenger Presence System																																																															
S	2009	Canyon	Body	Base Radio																																																															
S	2009	Canyon	Body	Uplevel Radio																																																															
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																																															
S	2009	Canyon	Body	Theft Deterrent Module																																																															
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																															
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																															
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																															
S	2009	Envoy	Chassis	Electronic Brake Control Module																																																															
S	2009	Envoy	Body	Body Control Module																																																															
S	2009	Envoy	Body	Digital Radio Receiver																																																															
S	2009	Envoy	Body	Disc Player and Video Display																																																															
S	2009	Envoy	Body	Driver Door Module																																																															
S	2009	Envoy	Body	Driver Seat Module																																																															
S	2009	Envoy	Body	Generator Battery Control Module																																																															
S	2009	Envoy	Body	HVAC Control Module Auto																																																															
S	2009	Envoy	Body	HVAC Control Module Manual																																																															
S	2009	Envoy	Body	Instrument Panel Cluster																																																															
S	2009	Envoy	Body	Lift Gate Module																																																															
S	2009	Envoy	Body	Passenger Door Module																																																															
S	2009	Envoy	Body	Passenger Presence System																																																															
S	2009	Envoy	Body	Uplevel Radio																																																															
S	2009	Envoy	Body	Navigation Radio																																																															
S	2009	Envoy	Body	Rear Seat Audio																																																															
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																																															
S	2009	Envoy	Body	Theft Deterrent Module																																																															
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																														
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																														
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																														
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																														
S	2010	ALL	Chassis	Electronic Brake Control Module																																																															
S	2010	ALL	Body	Body Control Module																																																															
S	2010	ALL	Body	Digital Radio Receiver																																																															
S	2010	ALL	Body	Generator Battery Control Module																																																															
S	2010	ALL	Body	Instument Panel Cluster																																																															
S	2010	ALL	Body	Passenger Presence System																																																															
S	2010	ALL	Body	Personal Audio Link Module																																																															
S	2010	ALL	Body	Base Radio																																																															
S	2010	ALL	Body	Uplevel Radio																																																															
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
S	2010	ALL	Body	Theft Deterrent Module																																																															
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																															
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																															
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																															
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																															
T	2004	Sonoma	Body	Body Control Module																																																															
T	2004	Sonoma	Body	Instrument Panel Cluster																																																															
T	2004	Sonoma	Body	Base Radio																																																															
T	2004	Sonoma	Body	Uplevel Radio																																																															
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																															
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																															
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																															
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																															
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																															
T	2004	Canyon	Chassis	ABS Without Traction Control																																																															
T	2004	Canyon	Chassis	ABS With Traction Control																																																															
T	2004	Canyon	Body	Body Control Module																																																															
T	2004	Canyon	Body	Instrument Panel Cluster																																																															
T	2004	Canyon	Body	OnStar																																																															
T	2004	Canyon	Body	Base Radio																																																															
T	2004	Canyon	Body	Uplevel Radio																																																															
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																																															
T	2004	Canyon	Body	Instrument Panel Cluster																																																															
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																															
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																															
T	2004	Envoy	Chassis	ABS Without Traction Control																																																															
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																															
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																															
T	2004	Envoy	Body	Amplifier (Bose)																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2004	Envoy	Body	Body Control Module																																																														
T	2004	Envoy	Body	Driver Door Module																																																														
T	2004	Envoy	Body	Driver Seat Module																																																														
T	2004	Envoy	Body	Heating and Air Conditioning Auto																																																														
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																																														
T	2004	Envoy	Body	Instrument Panel Cluster																																																														
T	2004	Envoy	Body	Lift Gate Module																																																														
T	2004	Envoy	Body	OnStar																																																														
T	2004	Envoy	Body	Passenger Door Module																																																														
T	2004	Envoy	Body	Uplevel Radio																																																														
T	2004	Envoy	Body	Navigation Radio																																																														
T	2004	Envoy	Body	Rear Seat Audio																																																														
T	2004	Envoy	Body	Rear Seat Entertainment																																																														
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																																														
T	2004	Envoy	Body	Vehicle Theft Deterrent																																																														
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																														
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																														
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																														
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																														
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																														
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																														
T	2004	Envoy XL	Body	Amplifier (Bose)																																																														
T	2004	Envoy XL	Body	Body Control Module																																																														
T	2004	Envoy XL	Body	Driver Door Module																																																														
T	2004	Envoy XL	Body	Driver Seat Module																																																														
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																														
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																														
T	2004	Envoy XL	Body	Instrument Panel Cluster																																																														
T	2004	Envoy XL	Body	Lift Gate Module																																																														
T	2004	Envoy XL	Body	OnStar																																																														
T	2004	Envoy XL	Body	Passenger Door Module																																																														
T	2004	Envoy XL	Body	Uplevel Radio																																																														
T	2004	Envoy XL	Body	Navigation Radio																																																														
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																														
T	2004	Envoy XL	Body	Rear HVAC Manual																																																														
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																														
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																														
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																														
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																														
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																														
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																														
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																														
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																														
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																														
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2004	Envoy XUV	Body	Body Control Module																																																														
T	2004	Envoy XUV	Body	Driver Door Module																																																														
T	2004	Envoy XUV	Body	Driver Seat Module																																																														
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																														
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																														
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																																														
T	2004	Envoy XUV	Body	Lift Gate Module																																																														
T	2004	Envoy XUV	Body	OnStar																																																														
T	2004	Envoy XUV	Body	Passenger Door Module																																																														
T	2004	Envoy XUV	Body	Uplevel Radio																																																														
T	2004	Envoy XUV	Body	Navigation Radio																																																														
T	2004	Envoy XUV	Body	Rear Seat Audio																																																														
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																														
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																														
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																														
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																														
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																														
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																														
T	2004	Jimmy	Body	Body Control Module																																																														
T	2004	Jimmy	Body	Heating and Air Conditioning																																																														
T	2004	Jimmy	Body	Instrument Panel Cluster																																																														
T	2004	Jimmy	Body	Memory Seat Module																																																														
T	2004	Jimmy	Body	Base Radio																																																														
T	2004	Jimmy	Body	Uplevel Radio																																																														
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																														
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																														
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																														
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																														
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																														
T	2005	Canyon	Chassis	ABS Without Traction Control																																																														
T	2005	Canyon	Chassis	ABS With Traction Control																																																														
T	2005	Canyon	Body	Body Control Module																																																														
T	2005	Canyon	Body	Instrument Panel Cluster																																																														
T	2005	Canyon	Body	Base Radio																																																														
T	2005	Canyon	Body	Uplevel Radio																																																														
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																																														
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																																														
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																														
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																													
T	2005	Envoy	Chassis	ABS Without Traction Control																																																														
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																														
T	2005	Envoy	Body	Body Control Module																																																														
T	2005	Envoy	Body	Disc Player and Video Display																																																														
T	2005	Envoy	Body	Driver Door Module																																																														
T	2005	Envoy	Body	Driver Seat Module																																																														
T	2005	Envoy	Body	Heating and Air Conditioning Auto																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																																													
T	2005	Envoy	Body	Instrument Panel Cluster																																																														
T	2005	Envoy	Body	Lift Gate Module																																																														
T	2005	Envoy	Body	Passenger Door Module																																																														
T	2005	Envoy	Body	Passenger Presence System																																																														
T	2005	Envoy	Body	Uplevel Radio																																																														
T	2005	Envoy	Body	Navigation Radio																																																														
T	2005	Envoy	Body	Rear Seat Audio																																																														
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																																														
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																																														
T	2005	Envoy	Body	Vehicle Theft Deterrent																																																														
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																														
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																						V																								
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																														
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																														
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																														
T	2005	Envoy XL	Body	Body Control Module																																																														
T	2005	Envoy XL	Body	Disc Player and Video Display																																																														
T	2005	Envoy XL	Body	Driver Door Module																																																														
T	2005	Envoy XL	Body	Driver Seat Module																																																														
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																														
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																														
T	2005	Envoy XL	Body	Instrument Panel Cluster																																																														
T	2005	Envoy XL	Body	Lift Gate Module																																																														
T	2005	Envoy XL	Body	Passenger Door Module																																																														
T	2005	Envoy XL	Body	Passenger Presence System																																																														
T	2005	Envoy XL	Body	Uplevel Radio																																																														
T	2005	Envoy XL	Body	Navigation Radio																																																														
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																														
T	2005	Envoy XL	Body	Rear HVAC Manual																																																														
T	2005	Envoy XL	Body	Rear Seat Audio																																																														
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																														
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																														
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																														
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																														
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																						V																								
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																														
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																														
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																														
T	2005	Envoy XUV	Body	Body Control Module																																																														
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																														
T	2005	Envoy XUV	Body	Driver Door Module																																																														
T	2005	Envoy XUV	Body	Driver Seat Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																														
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																														
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																																														
T	2005	Envoy XUV	Body	Lift Gate Module																																																														
T	2005	Envoy XUV	Body	Passenger Door Module																																																														
T	2005	Envoy XUV	Body	Passenger Presence System																																																														
T	2005	Envoy XUV	Body	Uplevel Radio																																																														
T	2005	Envoy XUV	Body	Navigation Radio																																																														
T	2005	Envoy XUV	Body	Rear Seat Audio																																																														
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																														
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																														
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																														
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																														
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																														
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																														
T	2005	Jimmy	Body	Body Control Module																																																														
T	2005	Jimmy	Body	Heating and Air Conditioning																																																														
T	2005	Jimmy	Body	Instrument Panel Cluster																																																														
T	2005	Jimmy	Body	Memory Seat Module																																																														
T	2005	Jimmy	Body	Base Radio																																																														
T	2005	Jimmy	Body	Uplevel Radio																																																														
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																														
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																														
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																														
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																														
T	2005	Sonoma	Body	Body Control Module																																																														
T	2005	Sonoma	Body	Instrument Panel Cluster																																																														
T	2005	Sonoma	Body	Base Radio																																																														
T	2005	Sonoma	Body	Uplevel Radio																																																														
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																														
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																														
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																														
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																														
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																														
T	2006	Canyon	Chassis	ABS Without Traction Control																																																														
T	2006	Canyon	Chassis	ABS With Traction Control																																																														
T	2006	Canyon	Body	Body Control Module																																																														
T	2006	Canyon	Body	Instrument Panel Cluster																																																														
T	2006	Canyon	Body	Passenger Presence System																																																														
T	2006	Canyon	Body	Base Radio																																																														
T	2006	Canyon	Body	Uplevel Radio																																																														
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																																														
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																																														
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																														
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																						V																								

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																						V																							
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2006	Envoy	Chassis	ABS/TCS/VSES																																																													
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																												
T	2006	Envoy	Body	Body Control Module																																																												
T	2006	Envoy	Body	Disc Player and Video Display																																																												
T	2006	Envoy	Body	Driver Door Module																																																												
T	2006	Envoy	Body	Driver Seat Module																																																												
T	2006	Envoy	Body	Heating and Air Conditioning Auto																																																												
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																																												
T	2006	Envoy	Body	Instrument Panel Cluster																																																												
T	2006	Envoy	Body	Lift Gate Module																																																												
T	2006	Envoy	Body	Passenger Door Module																																																												
T	2006	Envoy	Body	Passenger Presence System																																																												
T	2006	Envoy	Body	Uplevel Radio																																																												
T	2006	Envoy	Body	Navigation Radio																																																												
T	2006	Envoy	Body	Rear Seat Audio																																																												
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2006	Envoy	Body	Vehicle Theft Deterrent																																																												
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																																												
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																						V																							
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																												
T	2006	Envoy XL	Body	Body Control Module																																																												
T	2006	Envoy XL	Body	Disc Player and Video Display																																																												
T	2006	Envoy XL	Body	Driver Door Module																																																												
T	2006	Envoy XL	Body	Driver Seat Module																																																												
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
T	2006	Envoy XL	Body	Instrument Panel Cluster																																																												
T	2006	Envoy XL	Body	Lift Gate Module																																																												
T	2006	Envoy XL	Body	Passenger Door Module																																																												
T	2006	Envoy XL	Body	Passenger Presence System																																																												
T	2006	Envoy XL	Body	Uplevel Radio																																																												
T	2006	Envoy XL	Body	Navigation Radio																																																												
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
T	2006	Envoy XL	Body	Rear HVAC Manual																																																												
T	2006	Envoy XL	Body	Rear Seat Audio																																																												
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																												
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																												
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																V																													
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																V																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																															
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																															
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																															
T	2007	Canyon	Body	Body Control Module																																																															
T	2007	Canyon	Body	Digital Radio Receiver																																																															
T	2007	Canyon	Body	Generator Battery Control Module																																																															
T	2007	Canyon	Body	Instrument Panel Cluster																																																															
T	2007	Canyon	Body	Passenger Presence System																																																															
T	2007	Canyon	Body	Base Radio																																																															
T	2007	Canyon	Body	Uplevel Radio																																																															
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																																															
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																																															
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																V																															
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																															
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																V																															
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																															
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																															
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																															
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																															
T	2007	Envoy	Chassis	Electronic Brake Control Module																																																															
T	2007	Envoy	Body	Body Control Module																																																															
T	2007	Envoy	Body	Digital Radio Receiver																																																															
T	2007	Envoy	Body	Disc Player and Video Display																																																															
T	2007	Envoy	Body	Driver Door Module																																																															
T	2007	Envoy	Body	Driver Seat Module																																																															
T	2007	Envoy	Body	Generator Battery Control Module																																																															
T	2007	Envoy	Body	HVAC Control Module Auto																																																															
T	2007	Envoy	Body	HVAC Control Module Manual																																																															
T	2007	Envoy	Body	Instrument Panel Cluster																																																															
T	2007	Envoy	Body	Lift Gate Module																																																															
T	2007	Envoy	Body	Passenger Door Module																																																															
T	2007	Envoy	Body	Passenger Presence System																																																															
T	2007	Envoy	Body	Uplevel Radio																																																															
T	2007	Envoy	Body	Navigation Radio																																																															
T	2007	Envoy	Body	Rear Seat Audio																																																															
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																																															
T	2007	Envoy	Body	Theft Deterrent Module																																																															
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																																															
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																															
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																															
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2008	Canyon	Body	Body Control Module																																																														
T	2008	Canyon	Body	Digital Radio Receiver																																																														
T	2008	Canyon	Body	Generator Battery Control Module																																																														
T	2008	Canyon	Body	Instrument Panel Cluster																																																														
T	2008	Canyon	Body	Passenger Presence System																																																														
T	2008	Canyon	Body	Base Radio																																																														
T	2008	Canyon	Body	Uplevel Radio																																																														
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																																														
T	2008	Canyon	Body	Theft Deterrent Module																																																														
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																																														
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																														
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																														
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																														
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
T	2008	Envoy	Chassis	Electronic Brake Control Module																																																														
T	2008	Envoy	Body	Body Control Module																																																														
T	2008	Envoy	Body	Digital Radio Receiver																																																														
T	2008	Envoy	Body	Disc Player and Video Display																																																														
T	2008	Envoy	Body	Driver Door Module																																																														
T	2008	Envoy	Body	Driver Seat Module																																																														
T	2008	Envoy	Body	Generator Battery Control Module																																																														
T	2008	Envoy	Body	HVAC Control Module Auto																																																														
T	2008	Envoy	Body	HVAC Control Module Manual																																																														
T	2008	Envoy	Body	Instrument Panel Cluster																																																														
T	2008	Envoy	Body	Lift Gate Module																																																														
T	2008	Envoy	Body	Passenger Door Module																																																														
T	2008	Envoy	Body	Passenger Presence System																																																														
T	2008	Envoy	Body	Uplevel Radio																																																														
T	2008	Envoy	Body	Navigation Radio																																																														
T	2008	Envoy	Body	Rear Seat Audio																																																														
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																																														
T	2008	Envoy	Body	Theft Deterrent Module																																																														
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																																														
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																														
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																														
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																														
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																														
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																														
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																														
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																														
T	2009	Canyon	Chassis	Electronic Brake Control Module																																																														
T	2009	Canyon	Body	Body Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2009	Canyon	Body	Digital Radio Receiver																																																														
T	2009	Canyon	Body	Generator Battery Control Module																																																														
T	2009	Canyon	Body	Instrument Panel Cluster																																																														
T	2009	Canyon	Body	Passenger Presence System																																																														
T	2009	Canyon	Body	Base Radio																																																														
T	2009	Canyon	Body	Uplevel Radio																																																														
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																																														
T	2009	Canyon	Body	Theft Deterrent Module																																																														
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																														
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																														
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																														
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																														
T	2009	Envoy	Body	Body Control Module																																																														
T	2009	Envoy	Body	Digital Radio Receiver																																																														
T	2009	Envoy	Body	Disc Player and Video Display																																																														
T	2009	Envoy	Body	Driver Door Module																																																														
T	2009	Envoy	Body	Driver Seat Module																																																														
T	2009	Envoy	Body	Generator Battery Control Module																																																														
T	2009	Envoy	Body	HVAC Control Module Auto																																																														
T	2009	Envoy	Body	HVAC Control Module Manual																																																														
T	2009	Envoy	Body	Instrument Panel Cluster																																																														
T	2009	Envoy	Body	Lift Gate Module																																																														
T	2009	Envoy	Body	Passenger Door Module																																																														
T	2009	Envoy	Body	Passenger Presence System																																																														
T	2009	Envoy	Body	Uplevel Radio																																																														
T	2009	Envoy	Body	Navigation Radio																																																														
T	2009	Envoy	Body	Rear Seat Audio																																																														
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																																														
T	2009	Envoy	Body	Theft Deterrent Module																																																														
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																														
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																														
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																														
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																														
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																														
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																														
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																														
T	2010	ALL	Chassis	Electronic Brake Control Module																																																														
T	2010	ALL	Body	Body Control Module																																																														
T	2010	ALL	Body	Digital Radio Receiver																																																														
T	2010	ALL	Body	Generator Battery Control Module																																																														
T	2010	ALL	Body	Instrument Panel Cluster																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
T	2010	ALL	Body	Passenger Presence System																																																													
T	2010	ALL	Body	Personal Audio Link Module																																																														
T	2010	ALL	Body	Base Radio																																																														
T	2010	ALL	Body	Uplevel Radio																																																														
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																														
T	2010	ALL	Body	Theft Deterrent Module																																																														
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																														
V	2007	ALL	Powertrain	Engine Control Module																																																														
V	2007	ALL	Powertrain	Rear Drive System																																																														
V	2007	ALL	Powertrain	Transmission Control Module																																																														
V	2007	ALL	Chassis	Electronic Brake Control Module																																																														
V	2007	ALL	Body	Body Control Module																																																														
V	2007	ALL	Body	Digital Radio Receiver																																																														
V	2007	ALL	Body	Driver Door Switch																																																														
V	2007	ALL	Body	Head Up Display																																																														
V	2007	ALL	Body	Heated Seat Module																																																														
V	2007	ALL	Body	HVAC Control Module Auto																																																														
V	2007	ALL	Body	HVAC Control Module Manual																																																														
V	2007	ALL	Body	Instrument Panel Cluster																																																														
V	2007	ALL	Body	Lift Gate Module																																																														
V	2007	ALL	Body	Park Assist Module																																																														
V	2007	ALL	Body	Passenger Door Switch																																																														
V	2007	ALL	Body	Passenger Presence System																																																														
V	2007	ALL	Body	Radio																																																														
V	2007	ALL	Body	Rear HVAC/RSA																																																														
V	2007	ALL	Body	Rollover Sensor																																																														
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2007	ALL	Body	Theft Deterrent Module																																																														
V	2008	ALL	Powertrain	Engine Control Module																																																														
V	2008	ALL	Powertrain	Rear Drive System																																																														
V	2008	ALL	Powertrain	Transmission Control Module																																																														
V	2008	ALL	Chassis	Electronic Brake Control Module																																																														
V	2008	ALL	Body	Body Control Module																																																														
V	2008	ALL	Body	Digital Radio Receiver																																																														
V	2008	ALL	Body	Driver Door Switch																																																														
V	2008	ALL	Body	Head Up Display																																																														
V	2008	ALL	Body	Heated Seat Module																																																														
V	2008	ALL	Body	HVAC Control Module Auto																																																														
V	2008	ALL	Body	HVAC Control Module Manual																																																														
V	2008	ALL	Body	Instrument Panel Cluster																																																														
V	2008	ALL	Body	Lift Gate Module																																																														
V	2008	ALL	Body	Park Assist Module																																																														
V	2008	ALL	Body	Passenger Door Switch																																																														
V	2008	ALL	Body	Passenger Presence System																																																														
V	2008	ALL	Body	Radio																																																														
V	2008	ALL	Body	Rear HVAC/RSA																																																														
V	2008	ALL	Body	Rollover Sensor																																																														
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2008	ALL	Body	Theft Deterrent Module																																																														
V	2009	ALL	Powertrain	Engine Control Module																																																														
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
V	2009	ALL	Powertrain	Rear Drive System																																																													
V	2009	ALL	Powertrain	Transmission Control Module																																																													
V	2009	ALL	Chassis	Electronic Brake Control Module																																																													
V	2009	ALL	Body	Body Control Module																																																												
V	2009	ALL	Body	Digital Radio Receiver																																																												
V	2009	ALL	Body	Driver Door Switch																																																												
V	2009	ALL	Body	Head Up Display																																																												
V	2009	ALL	Body	Heated Seat Module																																																												
V	2009	ALL	Body	HVAC Control Module Auto																																																												
V	2009	ALL	Body	HVAC Control Module Manual																																																												
V	2009	ALL	Body	Instrument Panel Cluster																																																												
V	2009	ALL	Body	Lift Gate Module																																																												
V	2009	ALL	Body	Park Assist Module																																																												
V	2009	ALL	Body	Passenger Door Switch																																																												
V	2009	ALL	Body	Passenger Presence System																																																												
V	2009	ALL	Body	Radio																																																												
V	2009	ALL	Body	Rear HVAC/RSA																																																												
V	2009	ALL	Body	Rollover Sensor																																																												
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2009	ALL	Body	Theft Deterrent Module																																																												
V	2010	ALL	Powertrain	Engine Control Module																																																												
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2010	ALL	Powertrain	Rear Drive System																																																												
V	2010	ALL	Powertrain	Transmission Control Module																																																												
V	2010	ALL	Chassis	Electronic Brake Control Module																																																												
V	2010	ALL	Body	Body Control Module																																																												
V	2010	ALL	Body	Digital Radio Receiver																																																												
V	2010	ALL	Body	Driver Door Switch																																																												
V	2010	ALL	Body	Head Up Display																																																												
V	2010	ALL	Body	Heated Seat Module																																																												
V	2010	ALL	Body	HVAC Control Module Auto																																																												
V	2010	ALL	Body	HVAC Control Module Manual																																																												
V	2010	ALL	Body	Instrument Panel Cluster																																																												
V	2010	ALL	Body	Lift Gate Module																																																												
V	2010	ALL	Body	Park Assist Module																																																												
V	2010	ALL	Body	Passenger Door Switch																																																												
V	2010	ALL	Body	Passenger Presence System																																																												
V	2010	ALL	Body	Radio																																																												
V	2010	ALL	Body	Rear HVAC/RSA																																																												
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2010	ALL	Body	Theft Deterrent Module																																																												
V	2011	ALL	Powertrain	Engine Control Module																																																												
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2011	ALL	Powertrain	Rear Drive System																																																												
V	2011	ALL	Powertrain	Transmission Control Module																																																												
V	2011	ALL	Chassis	Electronic Brake Control Module																																																												
V	2011	ALL	Body	Body Control Module																																																												
V	2011	ALL	Body	Digital Radio Receiver																																																												
V	2011	ALL	Body	Driver Door Switch																																																												
V	2011	ALL	Body	Head Up Display																																																												
V	2011	ALL	Body	Heated Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
V	2011	ALL	Body	HVAC Control Module Auto																																																														
V	2011	ALL	Body	HVAC Control Module Manual																																																														
V	2011	ALL	Body	Instrument Panel Cluster																																																														
V	2011	ALL	Body	Lift Gate Module																																																														
V	2011	ALL	Body	Park Assist Module																																																														
V	2011	ALL	Body	Passenger Door Switch																																																														
V	2011	ALL	Body	Passenger Presence System																																																														
V	2011	ALL	Body	Radio																																																														
V	2011	ALL	Body	Rear HVAC/RSA																																																														
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2011	ALL	Body	Theft Deterrent Module																																																														
V	2012	ALL	Powertrain	Engine Control Module																																																														
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																														
V	2012	ALL	Powertrain	Rear Drive System																																																														
V	2012	ALL	Powertrain	Transmission Control Module																																																														
V	2012	ALL	Chassis	Electronic Brake Control Module																																																														
V	2012	ALL	Body	Body Control Module																																																														
V	2012	ALL	Body	Digital Radio Receiver																																																														
V	2012	ALL	Body	Driver Door Switch																																																														
V	2012	ALL	Body	Head Up Display																																																														
V	2012	ALL	Body	Heated Seat Module																																																														
V	2012	ALL	Body	HVAC Control Module Auto																																																														
V	2012	ALL	Body	HVAC Control Module Manual																																																														
V	2012	ALL	Body	Instrument Panel Cluster																																																														
V	2012	ALL	Body	Lift Gate Module																																																														
V	2012	ALL	Body	Park Assist Module																																																														
V	2012	ALL	Body	Passenger Door Switch																																																														
V	2012	ALL	Body	Passenger Presence System																																																														
V	2012	ALL	Body	Radio																																																														
V	2012	ALL	Body	Rear HVAC/RSA																																																														
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2012	ALL	Body	Theft Deterrent Module																																																														
V	2013	ALL	Powertrain	Engine Control Module																																																														
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																														
V	2013	ALL	Powertrain	Rear Drive System																																																														
V	2013	ALL	Powertrain	Transmission Control Module																																																														
V	2013	ALL	Chassis	Electronic Brake Control Module																																																														
V	2013	ALL	Body	Body Control Module																																																														
V	2013	ALL	Body	Digital Radio Receiver																																																														
V	2013	ALL	Body	Driver Door Switch																																																														
V	2013	ALL	Body	Head Up Display																																																														
V	2013	ALL	Body	Heated Seat Module																																																														
V	2013	ALL	Body	HVAC Control Module Auto																																																														
V	2013	ALL	Body	HVAC Control Module Manual																																																														
V	2013	ALL	Body	Instrument Panel Cluster																																																														
V	2013	ALL	Body	Left Side Object Detection Module																																																														
V	2013	ALL	Body	Lift Gate Module																																																														
V	2013	ALL	Body	Park Assist Module																																																														
V	2013	ALL	Body	Passenger Door Switch																																																														
V	2013	ALL	Body	Passenger Presence System																																																														
V	2013	ALL	Body	Radio																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
V	2013	ALL	Body	Rear HVAC/RSA																																																														
V	2013	ALL	Body	Right Side Object Detection Module																																																														
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																													
V	2013	ALL	Body	Theft Deterrent Module																																																													
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																													
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																													
V	2014	Acadia	Powertrain	Chassis Control Module																																																													
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																													
V	2014	Acadia	Chassis	Electronic Brake Control Module																																																													
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																													
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																													
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
V	2014	Acadia	Body	Passenger Presence Module																																																													
V	2014	Acadia	Body	Instrument Cluster																																																													
V	2014	Acadia	Body	Head-Up Display Module																																																													
V	2014	Acadia	Body	Radio																																																													
V	2014	Acadia	Body	Rear Audio Control Module																																																													
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																													
V	2014	Acadia	Body	Personal Audio Link Control Module																																																													
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																													
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																													
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																													
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																													
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																													
V	2014	Acadia	Body	Liftgate Control Module																																																													
V	2014	Acadia	Body	Seat Memory Control Module																																																													
V	2014	Acadia	Body	Front Seat Heating Control Module																																																													
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																													
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																													
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																													
V	2014	Acadia	Body	Parking Assist Control Module																																																													
V	2014	Acadia	Body	Frontview Camera Module																																																													
V	2014	Acadia	Body	Theft Deterrent Module																																																													
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																													
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																													
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																													
V	2015	Acadia	Chassis	Electronic Brake Control Module																																																													
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																													
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																													
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
V	2015	Acadia	Body	Passenger Presence Module																																																													
V	2015	Acadia	Body	Instrument Cluster																																																													
V	2015	Acadia	Body	Head-Up Display Module																																																													
V	2015	Acadia	Body	Radio																																																													
V	2015	Acadia	Body	Rear Audio Control Module																																																													
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																													
V	2015	Acadia	Body	Personal Audio Link Control Module																																																													
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																													
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																													
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																														
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																														
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																														
V	2015	Acadia	Body	Liftgate Control Module																																																														
V	2015	Acadia	Body	Seat Memory Control Module																																																														
V	2015	Acadia	Body	Front Seat Heating Control Module																																																														
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																														
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																														
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																														
V	2015	Acadia	Body	Parking Assist Control Module																																																														
V	2015	Acadia	Body	Frontview Camera Module																																																														
V	2015	Acadia	Body	Theft Deterrent Module																																																														
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																															
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																															
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																															
V	2016	Acadia	Chassis	Electronic Brake Control Module																																																															
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																															
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																															
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
V	2016	Acadia	Body	Passenger Presence Module																																																															
V	2016	Acadia	Body	Instrument Cluster																																																															
V	2016	Acadia	Body	Head-Up Display Module																																																															
V	2016	Acadia	Body	Radio																																																															
V	2016	Acadia	Body	Rear Audio Control Module																																																															
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																															
V	2016	Acadia	Body	Personal Audio Link Control Module																																																															
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																															
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																															
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																															
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																															
V	2016	Acadia	Body	Liftgate Control Module																																																															
V	2016	Acadia	Body	Seat Memory Control Module																																																															
V	2016	Acadia	Body	Front Seat Heating Control Module																																																															
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																															
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																															
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																															
V	2016	Acadia	Body	Parking Assist Control Module																																																															
V	2016	Acadia	Body	Frontview Camera Module																																																															
V	2016	Acadia	Body	Theft Deterrent Module																																																															
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																															
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																															
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																															
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																															
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																				
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																														
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																														
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																														
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V																				
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																														
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																														
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																														
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																															
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																															
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																															
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																															
1	2011	Sierra	Chassis	Electronic Suspension Control																																																															
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																															
1	2011	Sierra	Body	Amplifier (Bose)																																																															
1	2011	Sierra	Body	Body Control Module																																																															
1	2011	Sierra	Body	Body Control Module (aux.)																																																															
1	2011	Sierra	Body	Digital Radio Receiver																																																															
1	2011	Sierra	Body	Driver Door Switch																																																															
1	2011	Sierra	Body	HVAC Control Module Auto																																																															
1	2011	Sierra	Body	HVAC Control Module Manual																																																															
1	2011	Sierra	Body	Instrument Panel Cluster																																																															
1	2011	Sierra	Body	Memory Seat Module																																																															
1	2011	Sierra	Body	Park Assist Module																																																															
1	2011	Sierra	Body	Passenger Door Switch																																																															
1	2011	Sierra	Body	Passenger Presence System																																																															
1	2011	Sierra	Body	Radio																																																															
1	2011	Sierra	Body	Rear Heated Seat Module																																																															
1	2011	Sierra	Body	Rear HVAC/RSA																																																															
1	2011	Sierra	Body	Supplemental Inflatable Restraint																																																															
1	2011	Sierra	Body	Theft Deterrent Module																																																															
1	2011	Sierra Hybrid	Powertrain	Engine Control Module																																								V																				
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																															
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																															
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																															
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																															
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																															
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																															
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																															
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																															
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																															
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																															
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																															
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																															
1	2011	Sierra Hybrid	Body	Body Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																												
1	2011	Sierra Hybrid	Body	Driver Door Switch																																																												
1	2011	Sierra Hybrid	Body	Heated Seat Module																																																												
1	2011	Sierra Hybrid	Body	HVAC Control Module																																																												
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
1	2011	Sierra Hybrid	Body	Park Assist Module																																																												
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																																												
1	2011	Sierra Hybrid	Body	Passenger Presence System																																																												
1	2011	Sierra Hybrid	Body	Radio																																																												
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																												
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
1	2011	Yukon	Chassis	Electronic Brake Control Module																																																												
1	2011	Yukon	Chassis	Electronic Suspension Control																																																												
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																												
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
1	2011	Yukon	Body	Amplifier (Bose)																																																												
1	2011	Yukon	Body	Assist Step Controller																																																												
1	2011	Yukon	Body	Body Control Module																																																												
1	2011	Yukon	Body	Body Control Module (aux.)																																																												
1	2011	Yukon	Body	Digital Radio Receiver																																																												
1	2011	Yukon	Body	Driver Door Switch																																																												
1	2011	Yukon	Body	HVAC Control Module Auto																																																												
1	2011	Yukon	Body	HVAC Control Module Manual																																																												
1	2011	Yukon	Body	Instrument Panel Cluster																																																												
1	2011	Yukon	Body	Left Side Object Detection Module																																																												
1	2011	Yukon	Body	Lift Gate Module																																																												
1	2011	Yukon	Body	Memory Seat Module																																																												
1	2011	Yukon	Body	Park Assist Module																																																												
1	2011	Yukon	Body	Passenger Door Switch																																																												
1	2011	Yukon	Body	Passenger Presence System																																																												
1	2011	Yukon	Body	Radio																																																												
1	2011	Yukon	Body	Rear Heated Seat Module																																																												
1	2011	Yukon	Body	Rear HVAC/RSA																																																												
1	2011	Yukon	Body	Right Side Object Detection Module																																																												
1	2011	Yukon	Body	Supplemental Inflatable Restraint																																																												
1	2011	Yukon	Body	Theft Deterrent Module																																																												
1	2011	Yukon Hybrid	Powertrain	Engine Control Module																																									V																			
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																												
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																														
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																														
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																														
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																														
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																														
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																														
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																														
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																														
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																														
1	2011	Yukon Hybrid	Body	Body Control Module																																																														
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																														
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																														
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																														
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																														
1	2011	Yukon Hybrid	Body	HVAC Control Module																																																														
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																														
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																														
1	2011	Yukon Hybrid	Body	Lift Gate Module																																																														
1	2011	Yukon Hybrid	Body	Park Assist Module																																																														
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																														
1	2011	Yukon Hybrid	Body	Passenger Presence System																																																														
1	2011	Yukon Hybrid	Body	Radio																																																														
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																														
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																														
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																														
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																														
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																														
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																														
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																														
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																														
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																														
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																														
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																														
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																														
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																														
1	2011	Yukon XL	Body	Amplifier (Bose)																																																														
1	2011	Yukon XL	Body	Assist Step Controller																																																														
1	2011	Yukon XL	Body	Body Control Module																																																														
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																														
1	2011	Yukon XL	Body	Digital Radio Receiver																																																														
1	2011	Yukon XL	Body	Driver Door Switch																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2011	Yukon XL	Body	HVAC Control Module Auto																																																												
1	2011	Yukon XL	Body	HVAC Control Module Manual																																																												
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																												
1	2011	Yukon XL	Body	Left Side Object Detection Module																																																												
1	2011	Yukon XL	Body	Lift Gate Module																																																												
1	2011	Yukon XL	Body	Memory Seat Module																																																												
1	2011	Yukon XL	Body	Park Assist Module																																																												
1	2011	Yukon XL	Body	Passenger Door Switch																																																												
1	2011	Yukon XL	Body	Passenger Presence System																																																												
1	2011	Yukon XL	Body	Radio																																																												
1	2011	Yukon XL	Body	Rear Heated Seat Module																																																												
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																												
1	2011	Yukon XL	Body	Right Side Object Detection Module																																																												
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
1	2011	Yukon XL	Body	Theft Deterrent Module																																																												
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
1	2012	Sierra	Chassis	Electronic Suspension Control																																																												
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																												
1	2012	Sierra	Body	Amplifier (Bose)																																																												
1	2012	Sierra	Body	Body Control Module																																																												
1	2012	Sierra	Body	Body Control Module (aux.)																																																												
1	2012	Sierra	Body	Digital Radio Receiver																																																												
1	2012	Sierra	Body	Driver Door Switch																																																												
1	2012	Sierra	Body	HVAC Control Module Auto																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2012	Sierra	Body	HVAC Control Module Manual																																																														
1	2012	Sierra	Body	Instrument Panel Cluster																																																														
1	2012	Sierra	Body	Memory Seat Module																																																														
1	2012	Sierra	Body	Park Assist Module																																																														
1	2012	Sierra	Body	Passenger Door Switch																																																														
1	2012	Sierra	Body	Passenger Presence System																																																														
1	2012	Sierra	Body	Radio																																																														
1	2012	Sierra	Body	Navigation Radio																																																														
1	2012	Sierra	Body	Rear Heated Seat Module																																																														
1	2012	Sierra	Body	Rear HVAC/RSA																																																														
1	2012	Sierra	Body	Supplemental Inflatable Restraint																																																														
1	2012	Sierra	Body	Theft Deterrent Module																																																														
1	2012	Sierra Hybrid	Powertrain	Engine Control Module																																								V																					
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																														
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																														
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																														
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																														
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																														
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																														
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																														
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																														
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																														
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																														
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																														
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																														
1	2012	Sierra Hybrid	Body	Body Control Module																																																														
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																														
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																														
1	2012	Sierra Hybrid	Body	Driver Door Switch																																																														
1	2012	Sierra Hybrid	Body	Heated Seat Module																																																														
1	2012	Sierra Hybrid	Body	HVAC Control Module																																																														
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																														
1	2012	Sierra Hybrid	Body	Park Assist Module																																																														
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																																														
1	2012	Sierra Hybrid	Body	Passenger Presence System																																																														
1	2012	Sierra Hybrid	Body	Radio																																																														
1	2012	Sierra Hybrid	Body	Navigation Radio																																																														
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																														
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																														
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																														
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																														
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																														
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																														
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																														
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
1	2012	Yukon	Chassis	Electronic Brake Control Module																																																														
1	2012	Yukon	Chassis	Electronic Suspension Control																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																														
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																														
1	2012	Yukon	Body	Amplifier (Bose)																																																														
1	2012	Yukon	Body	Assist Step Controller																																																														
1	2012	Yukon	Body	Body Control Module																																																														
1	2012	Yukon	Body	Body Control Module (aux.)																																																														
1	2012	Yukon	Body	Digital Radio Receiver																																																														
1	2012	Yukon	Body	Driver Door Switch																																																														
1	2012	Yukon	Body	HVAC Control Module Auto																																																														
1	2012	Yukon	Body	HVAC Control Module Manual																																																														
1	2012	Yukon	Body	Instrument Panel Cluster																																																														
1	2012	Yukon	Body	Left Side Object Detection Module																																																														
1	2012	Yukon	Body	Lift Gate Module																																																														
1	2012	Yukon	Body	Memory Seat Module																																																														
1	2012	Yukon	Body	Park Assist Module																																																														
1	2012	Yukon	Body	Passenger Door Switch																																																														
1	2012	Yukon	Body	Passenger Presence System																																																														
1	2012	Yukon	Body	Radio																																																														
1	2012	Yukon	Body	Navigation Radio																																																														
1	2012	Yukon	Body	Rear Heated Seat Module																																																														
1	2012	Yukon	Body	Rear HVAC/RSA																																																														
1	2012	Yukon	Body	Right Side Object Detection Module																																																														
1	2012	Yukon	Body	Supplemental Inflatable Restraint																																																														
1	2012	Yukon	Body	Theft Deterrent Module																																																														
1	2012	Yukon Hybrid	Powertrain	Engine Control Module																																								V																					
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																														
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																														
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																														
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																														
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																														
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																														
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																														
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																														
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																														
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																														
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																														
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																														
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																														
1	2012	Yukon Hybrid	Body	Body Control Module																																																														
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																														
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																														
1	2012	Yukon Hybrid	Body	Driver Door Switch																																																														
1	2012	Yukon Hybrid	Body	Heated Seat Module																																																														
1	2012	Yukon Hybrid	Body	HVAC Control Module																																																														
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																														
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																														
1	2012	Yukon Hybrid	Body	Lift Gate Module																																																														
1	2012	Yukon Hybrid	Body	Park Assist Module																																																														
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																																														
1	2012	Yukon Hybrid	Body	Passenger Presence System																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2012	Yukon Hybrid	Body	Radio																																																														
1	2012	Yukon Hybrid	Body	Navigation Radio																																																														
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																														
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																														
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																														
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																														
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																														
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																														
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																														
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																														
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																														
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																														
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																														
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																														
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																														
1	2012	Yukon XL	Body	Amplifier (Bose)																																																														
1	2012	Yukon XL	Body	Assist Step Controller																																																														
1	2012	Yukon XL	Body	Body Control Module																																																														
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																														
1	2012	Yukon XL	Body	Digital Radio Receiver																																																														
1	2012	Yukon XL	Body	Driver Door Switch																																																														
1	2012	Yukon XL	Body	HVAC Control Module Auto																																																														
1	2012	Yukon XL	Body	HVAC Control Module Manual																																																														
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																														
1	2012	Yukon XL	Body	Left Side Object Detection Module																																																														
1	2012	Yukon XL	Body	Lift Gate Module																																																														
1	2012	Yukon XL	Body	Memory Seat Module																																																														
1	2012	Yukon XL	Body	Park Assist Module																																																														
1	2012	Yukon XL	Body	Passenger Door Switch																																																														
1	2012	Yukon XL	Body	Passenger Presence System																																																														
1	2012	Yukon XL	Body	Radio																																																														
1	2012	Yukon XL	Body	Navigation Radio																																																														
1	2012	Yukon XL	Body	Rear Heated Seat Module																																																														
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																														
1	2012	Yukon XL	Body	Right Side Object Detection Module																																																														
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																														
1	2012	Yukon XL	Body	Theft Deterrent Module																																																														
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																														
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																													
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																													
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																													
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																													
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																													
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																													
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V																				
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																													
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																													
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																													
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																													
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																													
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																													
1	2013	Sierra	Chassis	Electronic Suspension Control																																																													
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																													
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																													
1	2013	Sierra	Body	Amplifier (Bose)																																																													
1	2013	Sierra	Body	Body Control Module																																																													
1	2013	Sierra	Body	Body Control Module (aux.)																																																													
1	2013	Sierra	Body	Digital Radio Receiver																																																													
1	2013	Sierra	Body	Driver Door Switch																																																													
1	2013	Sierra	Body	HVAC Control Module Auto																																																													
1	2013	Sierra	Body	HVAC Control Module Manual																																																													
1	2013	Sierra	Body	Instrument Panel Cluster																																																													
1	2013	Sierra	Body	Memory Seat Module																																																													
1	2013	Sierra	Body	Park Assist Module																																																													
1	2013	Sierra	Body	Passenger Door Switch																																																													
1	2013	Sierra	Body	Passenger Presence System																																																													
1	2013	Sierra	Body	Radio																																																													
1	2013	Sierra	Body	Navigation Radio																																																													
1	2013	Sierra	Body	Rear Heated Seat Module																																																													
1	2013	Sierra	Body	Rear HVAC/RSA																																																													
1	2013	Sierra	Body	Supplemental Inflatable Restraint																																																													
1	2013	Sierra	Body	Theft Deterrent Module																																																													
1	2013	Sierra Hybrid	Powertrain	Engine Control Module																																								V																				
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																													
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																													
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																													
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																													
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																													
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																													
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																														
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																														
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																														
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																														
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																														
1	2013	Sierra Hybrid	Body	Body Control Module																																																														
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																														
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																														
1	2013	Sierra Hybrid	Body	Driver Door Switch																																																														
1	2013	Sierra Hybrid	Body	Heated Seat Module																																																														
1	2013	Sierra Hybrid	Body	HVAC Control Module																																																														
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																														
1	2013	Sierra Hybrid	Body	Park Assist Module																																																														
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																																														
1	2013	Sierra Hybrid	Body	Passenger Presence System																																																														
1	2013	Sierra Hybrid	Body	Radio																																																														
1	2013	Sierra Hybrid	Body	Navigation Radio																																																														
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																														
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																														
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																														
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																														
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																														
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																														
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																														
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
1	2013	Yukon	Chassis	Electronic Brake Control Module																																																														
1	2013	Yukon	Chassis	Electronic Suspension Control																																																														
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																														
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																														
1	2013	Yukon	Body	Amplifier (Bose)																																																														
1	2013	Yukon	Body	Assist Step Controller																																																														
1	2013	Yukon	Body	Body Control Module																																																														
1	2013	Yukon	Body	Body Control Module (aux.)																																																														
1	2013	Yukon	Body	Digital Radio Receiver																																																														
1	2013	Yukon	Body	Driver Door Switch																																																														
1	2013	Yukon	Body	HVAC Control Module Auto																																																														
1	2013	Yukon	Body	HVAC Control Module Manual																																																														
1	2013	Yukon	Body	Instrument Panel Cluster																																																														
1	2013	Yukon	Body	Left Side Object Detection Module																																																														
1	2013	Yukon	Body	Lift Gate Module																																																														
1	2013	Yukon	Body	Memory Seat Module																																																														
1	2013	Yukon	Body	Park Assist Module																																																														
1	2013	Yukon	Body	Passenger Door Switch																																																														
1	2013	Yukon	Body	Passenger Presence System																																																														
1	2013	Yukon	Body	Radio																																																														
1	2013	Yukon	Body	Navigation Radio																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2013	Yukon	Body	Rear Heated Seat Module																																																												
1	2013	Yukon	Body	Rear HVAC/RSA																																																												
1	2013	Yukon	Body	Right Side Object Detection Module																																																												
1	2013	Yukon	Body	Supplemental Inflatable Restraint																																																												
1	2013	Yukon	Body	Theft Deterrent Module																																																												
1	2013	Yukon Hybrid	Powertrain	Engine Control Module																																								V																		
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																												
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																												
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																												
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																												
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																												
1	2013	Yukon Hybrid	Body	Body Control Module																																																												
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																												
1	2013	Yukon Hybrid	Body	Driver Door Switch																																																												
1	2013	Yukon Hybrid	Body	Heated Seat Module																																																												
1	2013	Yukon Hybrid	Body	HVAC Control Module																																																												
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
1	2013	Yukon Hybrid	Body	Lift Gate Module																																																												
1	2013	Yukon Hybrid	Body	Park Assist Module																																																												
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																																												
1	2013	Yukon Hybrid	Body	Passenger Presence System																																																												
1	2013	Yukon Hybrid	Body	Radio																																																												
1	2013	Yukon Hybrid	Body	Navigation Radio																																																												
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																												
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																														
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																														
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																														
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																														
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																														
1	2013	Yukon XL	Body	Amplifier (Bose)																																																														
1	2013	Yukon XL	Body	Assist Step Controller																																																														
1	2013	Yukon XL	Body	Body Control Module																																																														
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																														
1	2013	Yukon XL	Body	Digital Radio Receiver																																																														
1	2013	Yukon XL	Body	Driver Door Switch																																																														
1	2013	Yukon XL	Body	HVAC Control Module Auto																																																														
1	2013	Yukon XL	Body	HVAC Control Module Manual																																																														
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																														
1	2013	Yukon XL	Body	Left Side Object Detection Module																																																														
1	2013	Yukon XL	Body	Lift Gate Module																																																														
1	2013	Yukon XL	Body	Memory Seat Module																																																														
1	2013	Yukon XL	Body	Park Assist Module																																																														
1	2013	Yukon XL	Body	Passenger Door Switch																																																														
1	2013	Yukon XL	Body	Passenger Presence System																																																														
1	2013	Yukon XL	Body	Radio																																																														
1	2013	Yukon XL	Body	Navigation Radio																																																														
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																														
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																														
1	2013	Yukon XL	Body	Right Side Object Detection Module																																																														
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																														
1	2013	Yukon XL	Body	Theft Deterrent Module																																																														
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																														
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																														
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																														
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																														
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																														
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																														
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																														
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																														
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																														
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
1	2014	Sierra	Chassis	Electronic Brake Control Module																																																														
1	2014	Sierra	Chassis	Parking Brake Control Module																																																														
1	2014	Sierra	Chassis	Power Steering Control Module																																																														
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																														
1	2014	Sierra	Body	Body Control Module																																																														
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
1	2014	Sierra	Body	Passenger Presence Module																																																														
1	2014	Sierra	Body	Instrument Cluster																																																														
1	2014	Sierra	Body	Radio Control																																																														
1	2014	Sierra	Body	HVAC Control																																																														
1	2014	Sierra	Body	Radio																																																														
1	2014	Sierra	Body	Amplifier																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2014	Sierra	Body	Media Disc Player																																																												
1	2014	Sierra	Body	Human Machine Interface Control Module																																																												
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
1	2014	Sierra	Body	Parking Assist Control Module																																																												
1	2014	Sierra	Body	Frontview Camera Module																																																												
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																												
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																												
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																												
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																												
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																												
1	2014	Sierra HD	Chassis	Suspension Control Module																																																												
1	2014	Sierra HD	Body	Body Control Module																																																												
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	Sierra HD	Body	Instrument Cluster																																																												
1	2014	Sierra HD	Body	Base Radio																																																												
1	2014	Sierra HD	Body	Navigation Radio																																																												
1	2014	Sierra HD	Body	Uplevel Radio																																																												
1	2014	Sierra HD	Body	Amplifier																																																												
1	2014	Sierra HD	Body	Rear Audio Control Module																																																												
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																												
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																												
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																												
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																												
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																												
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																												
1	2014	Sierra HD	Body	Seat Memory Control Module																																																												
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																												
1	2014	Sierra HD	Body	Parking Assist Control Module																																																												
1	2014	Sierra HD	Body	Theft Deterrent Module																																																												
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																												
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
1	2014	Yukon	Chassis	Electronic Brake Control Module																																																													
1	2014	Yukon	Chassis	Parking Brake Control Module																																																												
1	2014	Yukon	Chassis	Suspension Control Module																																																												
1	2014	Yukon	Body	Body Control Module																																																												
1	2014	Yukon	Body	Auxiliary Body Control Module																																																												
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	Yukon	Body	Passenger Presence Module																																																												
1	2014	Yukon	Body	Instrument Cluster																																																												
1	2014	Yukon	Body	Base Radio																																																												
1	2014	Yukon	Body	Navigation Radio																																																												
1	2014	Yukon	Body	Uplevel Radio																																																												
1	2014	Yukon	Body	Amplifier																																																												
1	2014	Yukon	Body	Rear Audio Control Module																																																												
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																																												
1	2014	Yukon	Body	Personal Audio Link Control Module																																																												
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																												
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																												
1	2014	Yukon	Body	Liftgate Control Module																																																												
1	2014	Yukon	Body	Seat Memory Control Module																																																												
1	2014	Yukon	Body	Rear Seat Heating Control Module																																																												
1	2014	Yukon	Body	Assist Step Control Module																																																												
1	2014	Yukon	Body	Right Side Object Detection Control Module																																																												
1	2014	Yukon	Body	Left Side Object Detection Control Module																																																												
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																																												
1	2014	Yukon	Body	Parking Assist Control Module																																																												
1	2014	Yukon	Body	Theft Deterrent Module																																																												
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																												
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																												
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																												
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																												
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																																												
1	2014	Yukon XL	Chassis	Suspension Control Module																																																												
1	2014	Yukon XL	Body	Body Control Module																																																												
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																																												
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	Yukon XL	Body	Passenger Presence Module																																																												
1	2014	Yukon XL	Body	Instrument Cluster																																																												
1	2014	Yukon XL	Body	Base Radio																																																												
1	2014	Yukon XL	Body	Navigation Radio																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2014	Yukon XL	Body	Uplevel Radio																																																												
1	2014	Yukon XL	Body	Amplifier																																																												
1	2014	Yukon XL	Body	Rear Audio Control Module																																																												
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																												
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																																												
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																												
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																												
1	2014	Yukon XL	Body	Liftgate Control Module																																																												
1	2014	Yukon XL	Body	Seat Memory Control Module																																																												
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																												
1	2014	Yukon XL	Body	Assist Step Control Module																																																												
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																												
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																												
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																												
1	2014	Yukon XL	Body	Parking Assist Control Module																																																												
1	2014	Yukon XL	Body	Theft Deterrent Module																																																												
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																											V	
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																												
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																												
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																												
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																												
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2015	Sierra	Chassis	Electronic Brake Control Module																																																												
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																												
1	2015	Sierra	Chassis	Power Steering Control Module																																																												
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2015	Sierra	Chassis	Suspension Control Module																														V	V																													
1	2015	Sierra	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
1	2015	Sierra	Body	Passenger Presence Module																																																													
1	2015	Sierra	Body	Instrument Cluster																																																													
1	2015	Sierra	Body	Radio Controls																																																													
1	2015	Sierra	Body	HVAC Controls																																																													
1	2015	Sierra	Body	Radio																																																													
1	2015	Sierra	Body	Amplifier																																																													
1	2015	Sierra	Body	Media Disc Player																																																													
1	2015	Sierra	Body	Human Machine Interface Control Module																																																													
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																													
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																													
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																													
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																													
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																													
1	2015	Sierra	Body	Parking Assist Control Module																																																													
1	2015	Sierra	Body	Frontview Camera Module																																																													
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																													
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																													
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																													
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																													
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																													
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																													
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																													
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																													
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																													
1	2015	Yukon	Chassis	Electronic Brake Control Module																																																													
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																													
1	2015	Yukon	Chassis	Parking Brake Control Module																																																													
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																													
1	2015	Yukon	Chassis	Power Steering Control Module																																																													
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																													
1	2015	Yukon	Chassis	Suspension Control Module																														V	V																														
1	2015	Yukon	Body	Body Control Module																																																													
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
1	2015	Yukon	Body	Passenger Presence Module																																																													
1	2015	Yukon	Body	Instrument Cluster																																																													
1	2015	Yukon	Body	Radio Controls																																																													
1	2015	Yukon	Body	HVAC Controls																																																													
1	2015	Yukon	Body	Radio																																																													
1	2015	Yukon	Body	Amplifier																																																													
1	2015	Yukon	Body	Media Disc Player																																																													
1	2015	Yukon	Body	Human Machine Interface Control Module																																																													
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																													
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																													
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2015	Yukon	Body	HVAC Control Module																																																												
1	2015	Yukon	Body	Liftgate Control Module																																																													
1	2015	Yukon	Body	Keyless Entry Control Module																																																												
1	2015	Yukon	Body	Assist Step Control Module																																																												
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																												
1	2015	Yukon	Body	Parking Assist Control Module																																																												
1	2015	Yukon	Body	Frontview Camera Module																																																												
1	2015	Yukon	Body	Steering Column Lock Control Module																																																												
1	2015	Yukon	Body	Battery Energy Control Module				V	V	V	V																																																					
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																												
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																												
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																												
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																												
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																												
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																												
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2015	Yukon XL	Chassis	Power Steering Control Module																																																												
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2015	Yukon XL	Chassis	Suspension Control Module																													V	V																													
1	2015	Yukon XL	Body	Body Control Module																																																												
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2015	Yukon XL	Body	Passenger Presence Module																																																												
1	2015	Yukon XL	Body	Instrument Cluster																																																												
1	2015	Yukon XL	Body	Radio Controls																																																												
1	2015	Yukon XL	Body	HVAC Controls																																																												
1	2015	Yukon XL	Body	Radio																																																												
1	2015	Yukon XL	Body	Amplifier																																																												
1	2015	Yukon XL	Body	Media Disc Player																																																												
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																												
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																												
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																												
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2015	Yukon XL	Body	HVAC Control Module																																																												
1	2015	Yukon XL	Body	Liftgate Control Module																																																												
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																												
1	2015	Yukon XL	Body	Assist Step Control Module																																																												
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																												
1	2015	Yukon XL	Body	Parking Assist Control Module																																																												
1	2015	Yukon XL	Body	Frontview Camera Module																																																												
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																												
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																												
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																												
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																												
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																												
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																												
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2					V	V		V																																																				
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																												
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2016	Sierra	Chassis	Electronic Brake Control Module																																																												
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																												
1	2016	Sierra	Chassis	Parking Brake Control Module																																																												
1	2016	Sierra	Chassis	Power Steering Control Module																																																												
1	2016	Sierra	Chassis	Power Steering Control Module																																																												
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2016	Sierra	Chassis	Suspension Control Module																														V	V																												
1	2016	Sierra	Body	Body Control Module																																																											
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2016	Sierra	Body	Passenger Presence Module																																																												
1	2016	Sierra	Body	Instrument Cluster																																																												
1	2016	Sierra	Body	Radio Controls																																																											
1	2016	Sierra	Body	HVAC Controls																																																											
1	2016	Sierra	Body	Radio (IO3)																																																											
1	2016	Sierra	Body	Radio (IOB)																																																											
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																											
1	2016	Sierra	Body	Amplifier																																																											
1	2016	Sierra	Body	Media Disc Player																																																											
1	2016	Sierra	Body	Human Machine Interface Control Module																																																											
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																											
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																											
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																											
1	2016	Sierra	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2016	Sierra	Body	Frontview Camera Module																																																											
1	2016	Sierra	Body	Frontview Camera Module																																																												
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2016	Yukon	Chassis	Electronic Brake Control Module																																																												
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																												
1	2016	Yukon	Chassis	Parking Brake Control Module																																																												
1	2016	Yukon	Chassis	Power Steering Control Module																																																												
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2016	Yukon	Chassis	Suspension Control Module																														V	V																													
1	2016	Yukon	Body	Body Control Module																																																												
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2016	Yukon	Body	Passenger Presence Module																																																												
1	2016	Yukon	Body	Instrument Cluster																																																												
1	2016	Yukon	Body	Radio Controls																																																												
1	2016	Yukon	Body	HVAC Controls																																																												
1	2016	Yukon	Body	Radio																																																												
1	2016	Yukon	Body	Amplifier																																																												
1	2016	Yukon	Body	Media Disc Player																																																												
1	2016	Yukon	Body	Human Machine Interface Control Module																																																												
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																												
1	2016	Yukon	Body	HVAC Control Module																																																												
1	2016	Yukon	Body	Liftgate Control Module																																																												
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																												
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																												
1	2016	Yukon	Body	Keyless Entry Control Module																																																												
1	2016	Yukon	Body	Assist Step Control Module																																																												
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																												
1	2016	Yukon	Body	Parking Assist Control Module																																																												
1	2016	Yukon	Body	Frontview Camera Module																																																												
1	2016	Yukon	Body	Steering Column Lock Control Module																																																												
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																												
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																												
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																												
1	2016	Yukon XL	Chassis	Power Steering Control Module																																																												
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2016	Yukon XL	Chassis	Suspension Control Module																														V	V																													
1	2016	Yukon XL	Body	Body Control Module																																																												
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
1	2016	Yukon XL	Body	Passenger Presence Module																																																												
1	2016	Yukon XL	Body	Instrument Cluster																																																												
1	2016	Yukon XL	Body	Radio Controls																																																												
1	2016	Yukon XL	Body	HVAC Controls																																																												
1	2016	Yukon XL	Body	Radio																																																												
1	2016	Yukon XL	Body	Amplifier																																																												
1	2016	Yukon XL	Body	Media Disc Player																																																												
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																												
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																												
1	2016	Yukon XL	Body	HVAC Control Module																																																												
1	2016	Yukon XL	Body	Liftgate Control Module																																																												
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																												
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																												
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																												
1	2016	Yukon XL	Body	Assist Step Control Module																																																												
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																												
1	2016	Yukon XL	Body	Parking Assist Control Module																																																												
1	2016	Yukon XL	Body	Frontview Camera Module																																																												
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																												
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																														
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																														
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																														
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																														
2	2011	Sierra	Chassis	Electronic Suspension Control																																																														
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																														
2	2011	Sierra	Body	Amplifier (Bose)																																																														
2	2011	Sierra	Body	Body Control Module																																																														
2	2011	Sierra	Body	Body Control Module (aux.)																																																														
2	2011	Sierra	Body	Digital Radio Receiver																																																														
2	2011	Sierra	Body	Driver Door Switch																																																														
2	2011	Sierra	Body	HVAC Control Module Auto																																																														
2	2011	Sierra	Body	HVAC Control Module Manual																																																														
2	2011	Sierra	Body	Instrument Panel Cluster																																																														
2	2011	Sierra	Body	Memory Seat Module																																																														
2	2011	Sierra	Body	Park Assist Module																																																														
2	2011	Sierra	Body	Passenger Door Switch																																																														
2	2011	Sierra	Body	Passenger Presence System																																																														
2	2011	Sierra	Body	Radio																																																														
2	2011	Sierra	Body	Rear Heated Seat Module																																																														
2	2011	Sierra	Body	Rear HVAC/RSA																																																														
2	2011	Sierra	Body	Supplemental Inflatable Restraint																																																														
2	2011	Sierra	Body	Theft Deterrent Module																																																														
2	2011	Sierra Hybrid	Powertrain	Engine Control Module																																								V																					
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																														
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																														
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																														
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																														
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																														
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																														
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																														
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																														
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																														
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																														
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																														
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																														
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																														
2	2011	Sierra Hybrid	Body	Body Control Module																																																														
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																														
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																														
2	2011	Sierra Hybrid	Body	Driver Door Switch																																																														
2	2011	Sierra Hybrid	Body	Heated Seat Module																																																														
2	2011	Sierra Hybrid	Body	HVAC Control Module																																																														
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																														
2	2011	Sierra Hybrid	Body	Park Assist Module																																																														
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																																														
2	2011	Sierra Hybrid	Body	Passenger Presence System																																																														
2	2011	Sierra Hybrid	Body	Radio																																																														
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																														
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																														
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																														
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																														
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																														
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																														
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																														
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																														
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
2	2011	Yukon	Chassis	Electronic Brake Control Module																																																														
2	2011	Yukon	Chassis	Electronic Suspension Control																																																														
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																														
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																														
2	2011	Yukon	Body	Amplifier (Bose)																																																														
2	2011	Yukon	Body	Assist Step Controller																																																														
2	2011	Yukon	Body	Body Control Module																																																														
2	2011	Yukon	Body	Body Control Module (aux.)																																																														
2	2011	Yukon	Body	Digital Radio Receiver																																																														
2	2011	Yukon	Body	Driver Door Switch																																																														
2	2011	Yukon	Body	HVAC Control Module Auto																																																														
2	2011	Yukon	Body	HVAC Control Module Manual																																																														
2	2011	Yukon	Body	Instrument Panel Cluster																																																														
2	2011	Yukon	Body	Left Side Object Detection Module																																																														
2	2011	Yukon	Body	Lift Gate Module																																																														
2	2011	Yukon	Body	Memory Seat Module																																																														
2	2011	Yukon	Body	Park Assist Module																																																														
2	2011	Yukon	Body	Passenger Door Switch																																																														
2	2011	Yukon	Body	Passenger Presence System																																																														
2	2011	Yukon	Body	Radio																																																														
2	2011	Yukon	Body	Rear Heated Seat Module																																																														
2	2011	Yukon	Body	Rear HVAC/RSA																																																														
2	2011	Yukon	Body	Right Side Object Detection Module																																																														
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																																														
2	2011	Yukon	Body	Theft Deterrent Module																																																														
2	2011	Yukon Hybrid	Powertrain	Engine Control Module																																								V																					
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																														
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																														
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																														
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																														
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																														
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																														
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																														
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																														
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																														
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																														
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																														
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																														
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																														
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																																
2	2011	Yukon Hybrid	Body	Body Control Module																																																																
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																																
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																																
2	2011	Yukon Hybrid	Body	Driver Door Switch																																																																
2	2011	Yukon Hybrid	Body	Heated Seat Module																																																																
2	2011	Yukon Hybrid	Body	HVAC Control Module																																																																
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																																
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																																
2	2011	Yukon Hybrid	Body	Lift Gate Module																																																																
2	2011	Yukon Hybrid	Body	Park Assist Module																																																																
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																																																
2	2011	Yukon Hybrid	Body	Passenger Presence System																																																																
2	2011	Yukon Hybrid	Body	Radio																																																																
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																																
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																																
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																																
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																																
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																																
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																																
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																																
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																																
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																																
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																																
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																																
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																																
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																																
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																																
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																																
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																																
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																																
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																																
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																																
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																																
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																																
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																																
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																																
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																																
2	2011	Yukon XL	Body	Amplifier (Bose)																																																																
2	2011	Yukon XL	Body	Assist Step Controller																																																																
2	2011	Yukon XL	Body	Body Control Module																																																																
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																																
2	2011	Yukon XL	Body	Digital Radio Receiver																																																																
2	2011	Yukon XL	Body	Driver Door Switch																																																																
2	2011	Yukon XL	Body	HVAC Control Module Auto																																																																
2	2011	Yukon XL	Body	HVAC Control Module Manual																																																																
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																																
2	2011	Yukon XL	Body	Left Side Object Detection Module																																																																

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2011	Yukon XL	Body	Lift Gate Module																																																														
2	2011	Yukon XL	Body	Memory Seat Module																																																														
2	2011	Yukon XL	Body	Park Assist Module																																																														
2	2011	Yukon XL	Body	Passenger Door Switch																																																														
2	2011	Yukon XL	Body	Passenger Presence System																																																														
2	2011	Yukon XL	Body	Radio																																																														
2	2011	Yukon XL	Body	Rear Heated Seat Module																																																														
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																														
2	2011	Yukon XL	Body	Right Side Object Detection Module																																																														
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																														
2	2011	Yukon XL	Body	Theft Deterrent Module																																																														
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																														
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																														
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																														
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																														
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																														
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																														
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																				
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																														
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																														
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																														
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																														
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V																				
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																														
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																														
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																														
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																														
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																														
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																														
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																														
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																														
2	2012	Sierra	Chassis	Electronic Suspension Control																																																														
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																														
2	2012	Sierra	Body	Amplifier (Bose)																																																														
2	2012	Sierra	Body	Body Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2012	Sierra	Body	Body Control Module (aux.)																																																												
2	2012	Sierra	Body	Digital Radio Receiver																																																												
2	2012	Sierra	Body	Driver Door Switch																																																												
2	2012	Sierra	Body	HVAC Control Module Auto																																																												
2	2012	Sierra	Body	HVAC Control Module Manual																																																												
2	2012	Sierra	Body	Instrument Panel Cluster																																																												
2	2012	Sierra	Body	Memory Seat Module																																																												
2	2012	Sierra	Body	Park Assist Module																																																												
2	2012	Sierra	Body	Passenger Door Switch																																																												
2	2012	Sierra	Body	Passenger Presence System																																																												
2	2012	Sierra	Body	Radio																																																												
2	2012	Sierra	Body	Navigation Radio																																																												
2	2012	Sierra	Body	Rear Heated Seat Module																																																												
2	2012	Sierra	Body	Rear HVAC/RSA																																																												
2	2012	Sierra	Body	Supplemental Inflatable Restraint																																																												
2	2012	Sierra	Body	Theft Deterrent Module																																																												
2	2012	Sierra Hybrid	Powertrain	Engine Control Module																																								V																				
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																												
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																												
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																												
2	2012	Sierra Hybrid	Body	Body Control Module																																																												
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																												
2	2012	Sierra Hybrid	Body	Driver Door Switch																																																												
2	2012	Sierra Hybrid	Body	Heated Seat Module																																																												
2	2012	Sierra Hybrid	Body	HVAC Control Module																																																												
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
2	2012	Sierra Hybrid	Body	Park Assist Module																																																												
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																																												
2	2012	Sierra Hybrid	Body	Passenger Presence System																																																												
2	2012	Sierra Hybrid	Body	Radio																																																												
2	2012	Sierra Hybrid	Body	Navigation Radio																																																												
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																												
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																													
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																													
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																													
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																													
2	2012	Yukon	Chassis	Electronic Brake Control Module																																																													
2	2012	Yukon	Chassis	Electronic Suspension Control																																																													
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																													
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																													
2	2012	Yukon	Body	Amplifier (Bose)																																																													
2	2012	Yukon	Body	Assist Step Controller																																																													
2	2012	Yukon	Body	Body Control Module																																																													
2	2012	Yukon	Body	Body Control Module (aux.)																																																													
2	2012	Yukon	Body	Digital Radio Receiver																																																													
2	2012	Yukon	Body	Driver Door Switch																																																													
2	2012	Yukon	Body	HVAC Control Module Auto																																																													
2	2012	Yukon	Body	HVAC Control Module Manual																																																													
2	2012	Yukon	Body	Instrument Panel Cluster																																																													
2	2012	Yukon	Body	Left Side Object Detection Module																																																													
2	2012	Yukon	Body	Lift Gate Module																																																													
2	2012	Yukon	Body	Memory Seat Module																																																													
2	2012	Yukon	Body	Park Assist Module																																																													
2	2012	Yukon	Body	Passenger Door Switch																																																													
2	2012	Yukon	Body	Passenger Presence System																																																													
2	2012	Yukon	Body	Radio																																																													
2	2012	Yukon	Body	Navigation Radio																																																													
2	2012	Yukon	Body	Rear Heated Seat Module																																																													
2	2012	Yukon	Body	Rear HVAC/RSA																																																													
2	2012	Yukon	Body	Right Side Object Detection Module																																																													
2	2012	Yukon	Body	Supplemental Inflatable Restraint																																																													
2	2012	Yukon	Body	Theft Deterrent Module																																																													
2	2012	Yukon Hybrid	Powertrain	Engine Control Module																																								V																			
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																													
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																													
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																													
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																													
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																													
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																													
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																													
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																													
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																													
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																													
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																													
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																													
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																													
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																													
2	2012	Yukon Hybrid	Body	Body Control Module																																																													
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																													
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																													
2	2012	Yukon Hybrid	Body	Driver Door Switch																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2012	Yukon Hybrid	Body	Heated Seat Module																																																															
2	2012	Yukon Hybrid	Body	HVAC Control Module																																																															
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																															
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																															
2	2012	Yukon Hybrid	Body	Lift Gate Module																																																															
2	2012	Yukon Hybrid	Body	Park Assist Module																																																															
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																																															
2	2012	Yukon Hybrid	Body	Passenger Presence System																																																															
2	2012	Yukon Hybrid	Body	Radio																																																															
2	2012	Yukon Hybrid	Body	Navigation Radio																																																															
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																															
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																															
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																															
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																															
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																															
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																															
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																															
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																															
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																															
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																															
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																															
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																															
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																															
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																															
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																															
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																															
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																															
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																															
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																															
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																															
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																															
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																															
2	2012	Yukon XL	Body	Amplifier (Bose)																																																															
2	2012	Yukon XL	Body	Assist Step Controller																																																															
2	2012	Yukon XL	Body	Body Control Module																																																															
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																															
2	2012	Yukon XL	Body	Digital Radio Receiver																																																															
2	2012	Yukon XL	Body	Driver Door Switch																																																															
2	2012	Yukon XL	Body	HVAC Control Module Auto																																																															
2	2012	Yukon XL	Body	HVAC Control Module Manual																																																															
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																															
2	2012	Yukon XL	Body	Left Side Object Detection Module																																																															
2	2012	Yukon XL	Body	Lift Gate Module																																																															
2	2012	Yukon XL	Body	Memory Seat Module																																																															
2	2012	Yukon XL	Body	Park Assist Module																																																															
2	2012	Yukon XL	Body	Passenger Door Switch																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2012	Yukon XL	Body	Passenger Presence System																																																														
2	2012	Yukon XL	Body	Radio																																																														
2	2012	Yukon XL	Body	Navigation Radio																																																														
2	2012	Yukon XL	Body	Rear Heated Seat Module																																																														
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																														
2	2012	Yukon XL	Body	Right Side Object Detection Module																																																														
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																														
2	2012	Yukon XL	Body	Theft Deterrent Module																																																														
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																														
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																														
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																														
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																														
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																														
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																														
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																														
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																														
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																														
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																														
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																														
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																														
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																														
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V																				
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																														
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																														
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																														
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																														
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																														
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																														
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																														
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																														
2	2013	Sierra	Chassis	Electronic Suspension Control																																																														
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																														
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																														
2	2013	Sierra	Body	Amplifier (Bose)																																																														
2	2013	Sierra	Body	Body Control Module																																																														
2	2013	Sierra	Body	Body Control Module (aux.)																																																														
2	2013	Sierra	Body	Digital Radio Receiver																																																														
2	2013	Sierra	Body	Driver Door Switch																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2013	Sierra	Body	HVAC Control Module Auto																																																										
2	2013	Sierra	Body	HVAC Control Module Manual																																																										
2	2013	Sierra	Body	Instrument Panel Cluster																																																										
2	2013	Sierra	Body	Memory Seat Module																																																										
2	2013	Sierra	Body	Park Assist Module																																																										
2	2013	Sierra	Body	Passenger Door Switch																																																										
2	2013	Sierra	Body	Passenger Presence System																																																										
2	2013	Sierra	Body	Radio																																																										
2	2013	Sierra	Body	Navigation Radio																																																										
2	2013	Sierra	Body	Rear Heated Seat Module																																																										
2	2013	Sierra	Body	Rear HVAC/RSA																																																										
2	2013	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2013	Sierra	Body	Theft Deterrent Module																																																										
2	2013	Sierra Hybrid	Powertrain	Engine Control Module																																								V																		
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Sierra Hybrid	Body	Body Control Module																																																										
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2013	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2013	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2013	Sierra Hybrid	Body	Park Assist Module																																																										
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2013	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2013	Sierra Hybrid	Body	Radio																																																										
2	2013	Sierra Hybrid	Body	Navigation Radio																																																										
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																														
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																														
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																														
2	2013	Yukon	Chassis	Electronic Brake Control Module																																																														
2	2013	Yukon	Chassis	Electronic Suspension Control																																																														
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																														
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																														
2	2013	Yukon	Body	Amplifier (Bose)																																																													
2	2013	Yukon	Body	Assist Step Controller																																																													
2	2013	Yukon	Body	Body Control Module																																																													
2	2013	Yukon	Body	Body Control Module (aux.)																																																													
2	2013	Yukon	Body	Digital Radio Receiver																																																													
2	2013	Yukon	Body	Driver Door Switch																																																													
2	2013	Yukon	Body	HVAC Control Module Auto																																																													
2	2013	Yukon	Body	HVAC Control Module Manual																																																													
2	2013	Yukon	Body	Instrument Panel Cluster																																																													
2	2013	Yukon	Body	Left Side Object Detection Module																																																													
2	2013	Yukon	Body	Lift Gate Module																																																													
2	2013	Yukon	Body	Memory Seat Module																																																													
2	2013	Yukon	Body	Park Assist Module																																																													
2	2013	Yukon	Body	Passenger Door Switch																																																													
2	2013	Yukon	Body	Passenger Presence System																																																													
2	2013	Yukon	Body	Radio																																																													
2	2013	Yukon	Body	Navigation Radio																																																													
2	2013	Yukon	Body	Rear Heated Seat Module																																																													
2	2013	Yukon	Body	Rear HVAC/RSA																																																													
2	2013	Yukon	Body	Right Side Object Detection Module																																																													
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																																													
2	2013	Yukon	Body	Theft Deterrent Module																																																													
2	2013	Yukon Hybrid	Powertrain	Engine Control Module																																								V																				
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																													
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																													
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																													
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																													
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																													
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																													
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																													
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																													
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																													
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																													
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																												
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																												
2	2013	Yukon Hybrid	Body	Body Control Module																																																												
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																												
2	2013	Yukon Hybrid	Body	Driver Door Switch																																																												
2	2013	Yukon Hybrid	Body	Heated Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2013	Yukon Hybrid	Body	HVAC Control Module																																																															
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																															
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																															
2	2013	Yukon Hybrid	Body	Lift Gate Module																																																															
2	2013	Yukon Hybrid	Body	Park Assist Module																																																															
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																																															
2	2013	Yukon Hybrid	Body	Passenger Presence System																																																															
2	2013	Yukon Hybrid	Body	Radio																																																															
2	2013	Yukon Hybrid	Body	Navigation Radio																																																															
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																															
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																															
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																															
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																															
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																															
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																															
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																															
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																															
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																															
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																															
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																															
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																															
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																															
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																															
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																															
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																															
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																															
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																															
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																															
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																															
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																															
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																															
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																															
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																															
2	2013	Yukon XL	Body	Amplifier (Bose)																																																															
2	2013	Yukon XL	Body	Assist Step Controller																																																															
2	2013	Yukon XL	Body	Body Control Module																																																															
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																															
2	2013	Yukon XL	Body	Digital Radio Receiver																																																															
2	2013	Yukon XL	Body	Driver Door Switch																																																															
2	2013	Yukon XL	Body	HVAC Control Module Auto																																																															
2	2013	Yukon XL	Body	HVAC Control Module Manual																																																															
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																															
2	2013	Yukon XL	Body	Left Side Object Detection Module																																																															
2	2013	Yukon XL	Body	Lift Gate Module																																																															
2	2013	Yukon XL	Body	Memory Seat Module																																																															
2	2013	Yukon XL	Body	Park Assist Module																																																															
2	2013	Yukon XL	Body	Passenger Door Switch																																																															
2	2013	Yukon XL	Body	Passenger Presence System																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2013	Yukon XL	Body	Radio																																																										
2	2013	Yukon XL	Body	Navigation Radio																																																										
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																										
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																										
2	2013	Yukon XL	Body	Right Side Object Detection Module																																																										
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
2	2013	Yukon XL	Body	Theft Deterrent Module																																																										
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2014	Sierra	Chassis	Electronic Brake Control Module																																																										
2	2014	Sierra	Chassis	Parking Brake Control Module																																																										
2	2014	Sierra	Chassis	Power Steering Control Module																																																										
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2014	Sierra	Body	Body Control Module																																																										
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Sierra	Body	Passenger Presence Module																																																										
2	2014	Sierra	Body	Instrument Cluster																																																										
2	2014	Sierra	Body	Radio Control																																																										
2	2014	Sierra	Body	HVAC Control																																																										
2	2014	Sierra	Body	Radio																																																										
2	2014	Sierra	Body	Amplifier																																																										
2	2014	Sierra	Body	Media Disc Player																																																										
2	2014	Sierra	Body	Human Machine Interface Control Module																																																										
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2014	Sierra	Body	Parking Assist Control Module																																																										
2	2014	Sierra	Body	Frontview Camera Module																																																										
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																								V		
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																										
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																										
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																										
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2014	Sierra HD	Chassis	Suspension Control Module																																																														
2	2014	Sierra HD	Body	Body Control Module																																																														
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
2	2014	Sierra HD	Body	Instrument Cluster																																																														
2	2014	Sierra HD	Body	Base Radio																																																														
2	2014	Sierra HD	Body	Navigation Radio																																																														
2	2014	Sierra HD	Body	Uplevel Radio																																																														
2	2014	Sierra HD	Body	Amplifier																																																														
2	2014	Sierra HD	Body	Rear Audio Control Module																																																														
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																														
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																														
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																														
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																														
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																														
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																														
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																														
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																														
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																														
2	2014	Sierra HD	Body	Seat Memory Control Module																																																														
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																														
2	2014	Sierra HD	Body	Parking Assist Control Module																																																														
2	2014	Sierra HD	Body	Theft Deterrent Module																																																														
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																														
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																														
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																														
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																														
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																														
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																														
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																														
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																														
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																														
2	2014	Yukon	Chassis	Parking Brake Control Module																																																														
2	2014	Yukon	Chassis	Suspension Control Module																																																														
2	2014	Yukon	Body	Body Control Module																																																														
2	2014	Yukon	Body	Auxiliary Body Control Module																																																														
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
2	2014	Yukon	Body	Passenger Presence Module																																																														
2	2014	Yukon	Body	Instrument Cluster																																																														
2	2014	Yukon	Body	Base Radio																																																														
2	2014	Yukon	Body	Navigation Radio																																																														
2	2014	Yukon	Body	Uplevel Radio																																																														
2	2014	Yukon	Body	Amplifier																																																														
2	2014	Yukon	Body	Rear Audio Control Module																																																														
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																														
2	2014	Yukon	Body	Personal Audio Link Control Module																																																														
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																														
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																														
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																														
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																														
2	2014	Yukon	Body	Liftgate Control Module																																																															
2	2014	Yukon	Body	Seat Memory Control Module																																																															
2	2014	Yukon	Body	Rear Seat Heating Control Module																																																															
2	2014	Yukon	Body	Assist Step Control Module																																																															
2	2014	Yukon	Body	Right Side Object Detection Control Module																																																															
2	2014	Yukon	Body	Left Side Object Detection Control Module																																																															
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																															
2	2014	Yukon	Body	Parking Assist Control Module																																																															
2	2014	Yukon	Body	Theft Deterrent Module																																																															
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																															
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																															
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																															
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																															
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																															
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																															
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																															
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																															
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																															
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																															
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																															
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																															
2	2014	Yukon XL	Chassis	Suspension Control Module																																																															
2	2014	Yukon XL	Body	Body Control Module																																																															
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																															
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
2	2014	Yukon XL	Body	Passenger Presence Module																																																															
2	2014	Yukon XL	Body	Instrument Cluster																																																															
2	2014	Yukon XL	Body	Base Radio																																																															
2	2014	Yukon XL	Body	Navigation Radio																																																															
2	2014	Yukon XL	Body	Uplevel Radio																																																															
2	2014	Yukon XL	Body	Amplifier																																																															
2	2014	Yukon XL	Body	Rear Audio Control Module																																																															
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																															
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																															
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																															
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																															
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																															
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																															
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																															
2	2014	Yukon XL	Body	Liftgate Control Module																																																															
2	2014	Yukon XL	Body	Seat Memory Control Module																																																															
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																															
2	2014	Yukon XL	Body	Assist Step Control Module																																																															
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																															
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																															
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																															
2	2014	Yukon XL	Body	Parking Assist Control Module																																																															
2	2014	Yukon XL	Body	Theft Deterrent Module																																																															
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																												V
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2015	Sierra	Chassis	Electronic Brake Control Module																																																												
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																												
2	2015	Sierra	Chassis	Power Steering Control Module																																																												
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2015	Sierra	Chassis	Suspension Control Module																														V	V																												
2	2015	Sierra	Body	Body Control Module																																																											
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2015	Sierra	Body	Passenger Presence Module																																																												
2	2015	Sierra	Body	Instrument Cluster																																																												
2	2015	Sierra	Body	Radio Controls																																																												
2	2015	Sierra	Body	HVAC Controls																																																												
2	2015	Sierra	Body	Radio																																																											
2	2015	Sierra	Body	Amplifier																																																											
2	2015	Sierra	Body	Media Disc Player																																																											
2	2015	Sierra	Body	Human Machine Interface Control Module																																																											
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																											
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
2	2015	Sierra	Body	Parking Assist Control Module																																																											
2	2015	Sierra	Body	Frontview Camera Module																																																											
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																												
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																												
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																												
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																												
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																												
2	2015	Yukon	Chassis	Electronic Brake Control Module																																																												
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																												
2	2015	Yukon	Chassis	Parking Brake Control Module																																																												
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																												
2	2015	Yukon	Chassis	Power Steering Control Module																																																												
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2015	Yukon	Chassis	Suspension Control Module																														V	V																													
2	2015	Yukon	Body	Body Control Module																																																												
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2015	Yukon	Body	Passenger Presence Module																																																												
2	2015	Yukon	Body	Instrument Cluster																																																												
2	2015	Yukon	Body	Radio Controls																																																												
2	2015	Yukon	Body	HVAC Controls																																																												
2	2015	Yukon	Body	Radio																																																												
2	2015	Yukon	Body	Amplifier																																																												
2	2015	Yukon	Body	Media Disc Player																																																												
2	2015	Yukon	Body	Human Machine Interface Control Module																																																												
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																												
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																												
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2015	Yukon	Body	HVAC Control Module																																																												
2	2015	Yukon	Body	Liftgate Control Module																																																												
2	2015	Yukon	Body	Keyless Entry Control Module																																																												
2	2015	Yukon	Body	Assist Step Control Module																																																												
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																												
2	2015	Yukon	Body	Parking Assist Control Module																																																												
2	2015	Yukon	Body	Frontview Camera Module																																																												
2	2015	Yukon	Body	Steering Column Lock Control Module																																																												
2	2015	Yukon	Body	Battery Energy Control Module				V	V	V	V																																																					
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																												
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																												
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																												
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																											
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																											
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																											
2	2015	Yukon XL	Chassis	Power Steering Control Module																																																											
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2015	Yukon XL	Chassis	Suspension Control Module																														V	V																												
2	2015	Yukon XL	Body	Body Control Module																																																											
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2015	Yukon XL	Body	Passenger Presence Module																																																											
2	2015	Yukon XL	Body	Instrument Cluster																																																											
2	2015	Yukon XL	Body	Radio Controls																																																											
2	2015	Yukon XL	Body	HVAC Controls																																																											
2	2015	Yukon XL	Body	Radio																																																											
2	2015	Yukon XL	Body	Amplifier																																																											
2	2015	Yukon XL	Body	Media Disc Player																																																											
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																											
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																											
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																											
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2015	Yukon XL	Body	HVAC Control Module																																																											
2	2015	Yukon XL	Body	Liftgate Control Module																																																											
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																											
2	2015	Yukon XL	Body	Assist Step Control Module																																																											
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																											
2	2015	Yukon XL	Body	Parking Assist Control Module																																																											
2	2015	Yukon XL	Body	Frontview Camera Module																																																											
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																											
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																											
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																											
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																											
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2					V	V		V																																																			
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																											
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																													
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																													
2	2016	Sierra	Chassis	Electronic Brake Control Module																																																													
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																													
2	2016	Sierra	Chassis	Parking Brake Control Module																																																													
2	2016	Sierra	Chassis	Power Steering Control Module																																																													
2	2016	Sierra	Chassis	Power Steering Control Module																																																													
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																													
2	2016	Sierra	Chassis	Suspension Control Module																														V	V																														
2	2016	Sierra	Body	Body Control Module																																																													
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
2	2016	Sierra	Body	Passenger Presence Module																																																													
2	2016	Sierra	Body	Instrument Cluster																																																													
2	2016	Sierra	Body	Radio Controls																																																													
2	2016	Sierra	Body	HVAC Controls																																																													
2	2016	Sierra	Body	Radio (IO3)																																																													
2	2016	Sierra	Body	Radio (IOB)																																																													
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																													
2	2016	Sierra	Body	Amplifier																																																													
2	2016	Sierra	Body	Media Disc Player																																																													
2	2016	Sierra	Body	Human Machine Interface Control Module																																																													
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																													
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																													
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																													
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																													
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																													
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																													
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																													
2	2016	Sierra	Body	Parking Assist Control Module																																																													
2	2016	Sierra	Body	Frontview Camera Module																																																													
2	2016	Sierra	Body	Frontview Camera Module																																																													
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																													
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																													
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																													
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2016	Yukon	Chassis	Electronic Brake Control Module																																																												
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																												
2	2016	Yukon	Chassis	Parking Brake Control Module																																																												
2	2016	Yukon	Chassis	Power Steering Control Module																																																												
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2016	Yukon	Chassis	Suspension Control Module																														V	V																													
2	2016	Yukon	Body	Body Control Module																																																												
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2016	Yukon	Body	Passenger Presence Module																																																												
2	2016	Yukon	Body	Instrument Cluster																																																												
2	2016	Yukon	Body	Radio Controls																																																												
2	2016	Yukon	Body	HVAC Controls																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
2	2016	Yukon	Body	Radio																																																												
2	2016	Yukon	Body	Amplifier																																																												
2	2016	Yukon	Body	Media Disc Player																																																												
2	2016	Yukon	Body	Human Machine Interface Control Module																																																												
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																												
2	2016	Yukon	Body	HVAC Control Module																																																												
2	2016	Yukon	Body	Liftgate Control Module																																																												
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																												
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																												
2	2016	Yukon	Body	Keyless Entry Control Module																																																												
2	2016	Yukon	Body	Assist Step Control Module																																																												
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																												
2	2016	Yukon	Body	Parking Assist Control Module																																																												
2	2016	Yukon	Body	Frontview Camera Module																																																												
2	2016	Yukon	Body	Steering Column Lock Control Module																																																												
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																												
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																												
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																												
2	2016	Yukon XL	Chassis	Power Steering Control Module																																																												
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2016	Yukon XL	Chassis	Suspension Control Module																														V	V																													
2	2016	Yukon XL	Body	Body Control Module																																																												
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2016	Yukon XL	Body	Passenger Presence Module																																																												
2	2016	Yukon XL	Body	Instrument Cluster																																																												
2	2016	Yukon XL	Body	Radio Controls																																																												
2	2016	Yukon XL	Body	HVAC Controls																																																												
2	2016	Yukon XL	Body	Radio																																																												
2	2016	Yukon XL	Body	Amplifier																																																												
2	2016	Yukon XL	Body	Media Disc Player																																																												
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																												
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																												
2	2016	Yukon XL	Body	HVAC Control Module																																																												
2	2016	Yukon XL	Body	Liftgate Control Module																																																												
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																												
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																												
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																												
2	2016	Yukon XL	Body	Assist Step Control Module																																																												
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																												
2	2016	Yukon XL	Body	Parking Assist Control Module																																																												
2	2016	Yukon XL	Body	Frontview Camera Module																																																												
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																												
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																													
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																													
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																													
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																													
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																													
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																													
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																													
5	2011	ALL	Chassis	Electronic Brake Control Module																																																														
5	2011	ALL	Body	Body Control Module																																																														
5	2011	ALL	Body	Digital Radio Receiver																																																														
5	2011	ALL	Body	Generator Battery Control Module																																																														
5	2011	ALL	Body	Instrument Panel Cluster																																																														
5	2011	ALL	Body	Passenger Presence System																																																														
5	2011	ALL	Body	Personal Audio Link Module																																																														
5	2011	ALL	Body	Base Radio																																																														
5	2011	ALL	Body	Uplevel Radio																																																														
5	2011	ALL	Body	Supplemental Inflatable Restraint																																																														
5	2011	ALL	Body	Theft Deterrent Module																																																														
5	2011	ALL	Body	Vehicle Comm. Interface Module																																																														
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																														
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																														
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																														
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																														
5	2012	ALL	Chassis	Electronic Brake Control Module																																																														
5	2012	ALL	Body	Body Control Module																																																														
5	2012	ALL	Body	Digital Radio Receiver																																																														
5	2012	ALL	Body	Generator Battery Control Module																																																														
5	2012	ALL	Body	Instrument Panel Cluster																																																														
5	2012	ALL	Body	Passenger Presence System																																																														
5	2012	ALL	Body	Personal Audio Link Module																																																														
5	2012	ALL	Body	Base Radio																																																														
5	2012	ALL	Body	Uplevel Radio																																																														
5	2012	ALL	Body	Supplemental Inflatable Restraint																																																														
5	2012	ALL	Body	Theft Deterrent Module																																																														
5	2012	ALL	Body	Vehicle Comm. Interface Module																																																														
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																														
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																														
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																													
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																													
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																														
5	2015	Canyon	Powertrain	Chassis Control Module																																																														
5	2015	Canyon	Powertrain	Transfer Case Control Module																																																														
5	2015	Canyon	Chassis	Electronic Brake Control Module																																																														
5	2015	Canyon	Chassis	Power Steering Control Module																																																														
5	2015	Canyon	Body	Body Control Module																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
5	2015	Canyon	Body	Passenger Presence Module																																																														
5	2015	Canyon	Body	Radio																																																													
5	2015	Canyon	Body	Amplifier																																																													
5	2015	Canyon	Body	Human Machine Interface Control Module																																																													
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																																													
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																													
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																													
5	2015	Canyon	Body	Parking Assist Control Module																																																													
5	2015	Canyon	Body	Frontview Camera Module																																																													
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																													
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																													
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																													
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
5	2016	Canyon	Powertrain	Transfer Case Control Module																																																													
5	2016	Canyon	Chassis	Electronic Brake Control Module																																																													
5	2016	Canyon	Chassis	Power Steering Control Module																																																													
5	2016	Canyon	Body	Body Control Module																																																													
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
5	2016	Canyon	Body	Passenger Presence Module																																																													
5	2016	Canyon	Body	Trailer Interface Control Module																																																													
5	2016	Canyon	Body	Radio																																																													
5	2016	Canyon	Body	Amplifier																																																													
5	2016	Canyon	Body	Human Machine Interface Control Module																																																													
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																																													
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																													
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																													
5	2016	Canyon	Body	Frontview Camera Module																																																													
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																													
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																													
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																													
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																													
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																													
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																													
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																													
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																													
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																													
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																													
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																													
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																													
6	2011	ALL	Chassis	Electronic Brake Control Module																																																													
6	2011	ALL	Body	Body Control Module																																																													
6	2011	ALL	Body	Digital Radio Receiver																																																													
6	2011	ALL	Body	Generator Battery Control Module																																																													
6	2011	ALL	Body	Instrument Panel Cluster																																																													
6	2011	ALL	Body	Passenger Presence System																																																													
6	2011	ALL	Body	Personal Audio Link Module																																																													
6	2011	ALL	Body	Base Radio																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
6	2011	ALL	Body	Uplevel Radio																																																														
6	2011	ALL	Body	Supplemental Inflatable Restraint																																																														
6	2011	ALL	Body	Theft Deterrent Module																																																														
6	2011	ALL	Body	Vehicle Comm. Interface Module																																																														
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																														
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																														
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																														
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																														
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																														
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																														
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																														
6	2012	ALL	Chassis	Electronic Brake Control Module																																																															
6	2012	ALL	Body	Body Control Module																																																															
6	2012	ALL	Body	Digital Radio Receiver																																																															
6	2012	ALL	Body	Generator Battery Control Module																																																															
6	2012	ALL	Body	Instrument Panel Cluster																																																															
6	2012	ALL	Body	Passenger Presence System																																																															
6	2012	ALL	Body	Personal Audio Link Module																																																															
6	2012	ALL	Body	Base Radio																																																															
6	2012	ALL	Body	Uplevel Radio																																																															
6	2012	ALL	Body	Supplemental Inflatable Restraint																																																															
6	2012	ALL	Body	Theft Deterrent Module																																																															
6	2012	ALL	Body	Vehicle Comm. Interface Module																																																															
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																															
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																															
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																															
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																															
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																															
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																															
6	2015	Canyon	Powertrain	Chassis Control Module																																																															
6	2015	Canyon	Powertrain	Transfer Case Control Module																																																															
6	2015	Canyon	Chassis	Electronic Brake Control Module																																																															
6	2015	Canyon	Chassis	Power Steering Control Module																																																															
6	2015	Canyon	Body	Body Control Module																																																															
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
6	2015	Canyon	Body	Passenger Presence Module																																																															
6	2015	Canyon	Body	Radio																																																															
6	2015	Canyon	Body	Amplifier																																																															
6	2015	Canyon	Body	Human Machine Interface Control Module																																																															
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																																															
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																															
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																															
6	2015	Canyon	Body	Parking Assist Control Module																																																															
6	2015	Canyon	Body	Frontview Camera Module																																																															
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																															
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																															

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																												
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
6	2016	Canyon	Powertrain	Transfer Case Control Module																																																												
6	2016	Canyon	Chassis	Electronic Brake Control Module																																																												
6	2016	Canyon	Chassis	Power Steering Control Module																																																												
6	2016	Canyon	Body	Body Control Module																																																												
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
6	2016	Canyon	Body	Passenger Presence Module																																																												
6	2016	Canyon	Body	Trailer Interface Control Module																																																												
6	2016	Canyon	Body	Radio																																																												
6	2016	Canyon	Body	Amplifier																																																												
6	2016	Canyon	Body	Human Machine Interface Control Module																																																												
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																																												
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																												
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																												
6	2016	Canyon	Body	Frontview Camera Module																																																												
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																				
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2011	Express/Savana	Body	Body Control Module																																																												
7	2011	Express/Savana	Body	Digital Radio Receiver																																																												
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																												
7	2011	Express/Savana	Body	Passenger Presence System																																																												
7	2011	Express/Savana	Body	Radio																																																												
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
7	2011	Express/Savana	Body	Rollover Sensor																																																												
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
7	2011	Express/Savana	Body	Theft Deterrent Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																			
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2011	Express Access/Savana Pro	Body	Body Control Module																																																												
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																												
7	2011	Express Access/Savana Pro	Body	Radio																																																												
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																												
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																			
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2012	Express/Savana	Body	Body Control Module																																																												
7	2012	Express/Savana	Body	Digital Radio Receiver																																																												
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																												
7	2012	Express/Savana	Body	Passenger Presence System																																																												
7	2012	Express/Savana	Body	Radio																																																												
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
7	2012	Express/Savana	Body	Rollover Sensor																																																												
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
7	2012	Express/Savana	Body	Theft Deterrent Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																			
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2012	Express Access/Savana Pro	Body	Body Control Module																																																												
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																												
7	2012	Express Access/Savana Pro	Body	Radio																																																												
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																												
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																			
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2013	Express/Savana	Body	Body Control Module																																																												
7	2013	Express/Savana	Body	Digital Radio Receiver																																																												
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																												
7	2013	Express/Savana	Body	Passenger Presence System																																																												
7	2013	Express/Savana	Body	Radio																																																												
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
7	2013	Express/Savana	Body	Rollover Sensor																																																												
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
7	2013	Express/Savana	Body	Theft Deterrent Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V																			
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2013	Express Access/Savana Pro	Body	Body Control Module																																																												
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																												
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																												
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																												
7	2013	Express Access/Savana Pro	Body	Radio																																																												
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																												
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																												
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
7	2014	Savana	Chassis	Electronic Brake Control Module																																																												
7	2014	Savana	Body	Body Control Module																																																												
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
7	2014	Savana	Body	Passenger Presence Module																																																												
7	2014	Savana	Body	Rollover Sensor Module																																																												
7	2014	Savana	Body	Instrument Cluster																																																												
7	2014	Savana	Body	Chime Alarm Control Module																																																												
7	2014	Savana	Body	Base Radio																																																												
7	2014	Savana	Body	Navigation Radio																																																												
7	2014	Savana	Body	Uplevel Radio																																																												
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																												
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																												
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
7	2014	Savana	Body	Auxiliary Heater Control Module																																																										
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2014	Savana	Body	Parking Assist Control Module																																																										
7	2014	Savana	Body	Theft Deterrent Module																																																										
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2015	Savana	Chassis	Electronic Brake Control Module																																																										
7	2015	Savana	Body	Body Control Module																																																										
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2015	Savana	Body	Rollover Sensor Module																																																										
7	2015	Savana	Body	Instrument Cluster																																																										
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
7	2015	Savana	Body	Auxiliary Heater Control Module																																																										
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2015	Savana	Body	Parking Assist Control Module																																																										
7	2015	Savana	Body	Theft Deterrent Module																																																										
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2016	Savana	Chassis	Electronic Brake Control Module																																																										
7	2016	Savana	Body	Body Control Module																																																										
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2016	Savana	Body	Instrument Cluster																																																										
7	2016	Savana	Body	Chime Alarm Control Module																																																										
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
7	2016	Savana	Body	Auxiliary Heater Control Module																																																										
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2016	Savana	Body	Parking Assist Control Module																																																										
7	2016	Savana	Body	Theft Deterrent Module																																																										
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																														
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																														
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																														
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																														
8	2011	Express/Savana	Body	Body Control Module																																																														
8	2011	Express/Savana	Body	Digital Radio Receiver																																																														
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																														
8	2011	Express/Savana	Body	Passenger Presence System																																																														
8	2011	Express/Savana	Body	Radio																																																														
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																														
8	2011	Express/Savana	Body	Rollover Sensor																																																														
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																														
8	2011	Express/Savana	Body	Theft Deterrent Module																																																														
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																														
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																														
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																														
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																														
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																														
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																														
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																														
8	2011	Express Access/Savana Pro	Body	Body Control Module																																																														
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																														
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																														
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																														
8	2011	Express Access/Savana Pro	Body	Radio																																																														
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																														
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																														
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																														
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																														
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																														
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																														
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																														
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																														
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																														
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																														
8	2012	Express/Savana	Body	Body Control Module																																																														
8	2012	Express/Savana	Body	Digital Radio Receiver																																																														
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																														
8	2012	Express/Savana	Body	Passenger Presence System																																																														
8	2012	Express/Savana	Body	Radio																																																														
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																														

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
8	2012	Express/Savana	Body	Rollover Sensor																																																												
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
8	2012	Express/Savana	Body	Theft Deterrent Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2012	Express Access/Savana Pro	Body	Body Control Module																																																												
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																												
8	2012	Express Access/Savana Pro	Body	Radio																																																												
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																												
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2013	Express/Savana	Body	Body Control Module																																																												
8	2013	Express/Savana	Body	Digital Radio Receiver																																																												
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																												
8	2013	Express/Savana	Body	Navigation Radio																																																												
8	2013	Express/Savana	Body	Park Assist Module																																																												
8	2013	Express/Savana	Body	Passenger Presence System																																																												
8	2013	Express/Savana	Body	Radio																																																												
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
8	2013	Express/Savana	Body	Rollover Sensor																																																												
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
8	2013	Express/Savana	Body	Theft Deterrent Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2013	Express Access/Savana Pro	Body	Body Control Module																																																												
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																												
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																																												
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																												
8	2013	Express Access/Savana Pro	Body	Radio																																																												
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																												
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																												
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																												
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
8	2014	Savana	Chassis	Electronic Brake Control Module																																																											
8	2014	Savana	Body	Body Control Module																																																											
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
8	2014	Savana	Body	Passenger Presence Module																																																											
8	2014	Savana	Body	Rollover Sensor Module																																																											
8	2014	Savana	Body	Instrument Cluster																																																											
8	2014	Savana	Body	Chime Alarm Control Module																																																											
8	2014	Savana	Body	Base Radio																																																											
8	2014	Savana	Body	Navigation Radio																																																											
8	2014	Savana	Body	Uplevel Radio																																																											
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																											
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											
8	2014	Savana	Body	Auxiliary Heater Control Module																																																											
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																											
8	2014	Savana	Body	Parking Assist Control Module																																																											
8	2014	Savana	Body	Theft Deterrent Module																																																											
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																													
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																													
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																												V		
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																													
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
8	2015	Savana	Chassis	Electronic Brake Control Module																																																													
8	2015	Savana	Body	Body Control Module																																																													
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
8	2015	Savana	Body	Rollover Sensor Module																																																													
8	2015	Savana	Body	Instrument Cluster																																																													
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																													
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																													
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																													
8	2015	Savana	Body	Auxiliary Heater Control Module																																																													
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																													
8	2015	Savana	Body	Parking Assist Control Module																																																													
8	2015	Savana	Body	Theft Deterrent Module																																																													
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																													
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																													
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																													
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																													
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																													
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																												V		
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																													
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
8	2016	Savana	Chassis	Electronic Brake Control Module																																																													
8	2016	Savana	Body	Body Control Module																																																													
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
8	2016	Savana	Body	Instrument Cluster																																																													
8	2016	Savana	Body	Chime Alarm Control Module																																																													
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																													
8	2016	Savana	Body	Telematics Communication Interface Control Module																																																													
8	2016	Savana	Body	Auxiliary Heater Control Module																																																													
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																													
8	2016	Savana	Body	Parking Assist Control Module																																																													
8	2016	Savana	Body	Theft Deterrent Module																																																													
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																													
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																													
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																													
ALL	2004	ALL	Chassis	ABS																																																													
ALL	2004	ALL	Chassis	Air Suspension																																																													
ALL	2004	ALL	Body	Amplifier (Bose)																																																													
ALL	2004	ALL	Body	Body Control Module																																																													
ALL	2004	ALL	Body	Digital Radio Receiver																																																													
ALL	2004	ALL	Body	Driver Door Module																																																													
ALL	2004	ALL	Body	Driver Seat Module																																																													
ALL	2004	ALL	Body	Heating and Air Conditioning																																																													
ALL	2004	ALL	Body	Instrument Panel Cluster																																																													
ALL	2004	ALL	Body	OnStar																																																													
ALL	2004	ALL	Body	Passenger Door Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
ALL	2004	ALL	Body	Uplevel Radio																																																												
ALL	2004	ALL	Body	Navigation Radio																																																												
ALL	2004	ALL	Body	Rear Seat Audio																																																												
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																												
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																												
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																												
ALL	2005	ALL	Chassis	ABS																																																												
ALL	2005	ALL	Chassis	Air Suspension																																																												
ALL	2005	ALL	Body	Body Control Module																																																												
ALL	2005	ALL	Body	Digital Radio Receiver																																																												
ALL	2005	ALL	Body	Driver Door Module (SUV)																																																												
ALL	2005	ALL	Body	Driver Door Module (SUT)																																																												
ALL	2005	ALL	Body	Driver Seat Module																																																												
ALL	2005	ALL	Body	Heating and Air Conditioning																																																												
ALL	2005	ALL	Body	Instrument Panel Cluster																																																												
ALL	2005	ALL	Body	Passenger Door Module																																																												
ALL	2005	ALL	Body	Uplevel Radio																																																												
ALL	2005	ALL	Body	Navigation Radio																																																												
ALL	2005	ALL	Body	Rear Seat Audio																																																												
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																												
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																												
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																												
ALL	2006	H2	Chassis	ABS																																																												
ALL	2006	H2	Chassis	Air Suspension																																																												
ALL	2006	H2	Body	Body Control Module																																																												
ALL	2006	H2	Body	Digital Radio Receiver																																																												
ALL	2006	H2	Body	Driver Door Module (SUV)																																																												
ALL	2006	H2	Body	Driver Door Module (SUT)																																																												
ALL	2006	H2	Body	Driver Seat Module																																																												
ALL	2006	H2	Body	Heating and Air Conditioning																																																												
ALL	2006	H2	Body	Instrument Panel Cluster																																																												
ALL	2006	H2	Body	Passenger Door Module																																																												
ALL	2006	H2	Body	Uplevel Radio																																																												
ALL	2006	H2	Body	Navigation Radio																																																												
ALL	2006	H2	Body	Rear Seat Audio																																																												
ALL	2006	H2	Body	Supplemental Inflatable Restraint																																																												
ALL	2006	H3	Powertrain	Engine Control Module																																V																												
ALL	2006	H3	Powertrain	Transmission Control Module																																																												
ALL	2006	H3	Powertrain	Transfer Case Control Module																																																												
ALL	2006	H3	Chassis	Antilock Brake System																																																												
ALL	2006	H3	Body	Body Control Module																																																												
ALL	2006	H3	Body	Digital Radio Receiver																																																												
ALL	2006	H3	Body	Instrument Panel Cluster																																																												
ALL	2006	H3	Body	Uplevel Radio																																																												
ALL	2006	H3	Body	Navigation Radio																																																												
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																																												
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																												
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																												
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
ALL	2007	H2	Chassis	ABS																																																												
ALL	2007	H2	Chassis	Air Suspension																																																												
ALL	2007	H2	Body	Amplifier (Bose)																																																												
ALL	2007	H2	Body	Body Control Module																																																												
ALL	2007	H2	Body	Digital Radio Receiver																																																												
ALL	2007	H2	Body	Driver Door Module (SUV)																																																												
ALL	2007	H2	Body	Driver Door Module (SUT)																																																												
ALL	2007	H2	Body	Driver Seat Module																																																												
ALL	2007	H2	Body	HVAC Control Module																																																												
ALL	2007	H2	Body	Instrument Panel Cluster																																																												
ALL	2007	H2	Body	Passenger Door Module																																																												
ALL	2007	H2	Body	Uplevel Radio																																																												
ALL	2007	H2	Body	Navigation Radio																																																												
ALL	2007	H2	Body	Rear Seat Audio																																																												
ALL	2007	H2	Body	Supplemental Inflatable Restraint																																																												
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																																												
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																															V																													
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																												
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																												
ALL	2007	H3	Chassis	EBCM																																																												
ALL	2007	H3	Body	Body Control Module (5GT)																																																												
ALL	2007	H3	Body	Body Control Module (ADM)																																																												
ALL	2007	H3	Body	Digital Radio Receiver																																																												
ALL	2007	H3	Body	Generator Battery Control Module																																																												
ALL	2007	H3	Body	Instrument Panel Cluster																																																												
ALL	2007	H3	Body	Personal Audio Link Module																																																												
ALL	2007	H3	Body	Uplevel Radio																																																												
ALL	2007	H3	Body	Navigation Radio																																																												
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																																												
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																									V																			
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																												
ALL	2008	H2	Chassis	Air SCM																																																												
ALL	2008	H2	Chassis	EBCM																																																												
ALL	2008	H2	Body	Amplifier (Bose)																																																												
ALL	2008	H2	Body	Body Control Module																																																												
ALL	2008	H2	Body	Digital Radio Receiver																																																												
ALL	2008	H2	Body	Driver Door Switch																																																												
ALL	2008	H2	Body	HVAC Control Module																																																												
ALL	2008	H2	Body	Instrument Panel Cluster																																																												
ALL	2008	H2	Body	Memory Seat Module																																																												
ALL	2008	H2	Body	Passenger Door Switch																																																												
ALL	2008	H2	Body	Radio																																																												
ALL	2008	H2	Body	Rear Heated Seat Module																																																												
ALL	2008	H2	Body	Rear HVAC/RSA																																																												
ALL	2008	H2	Body	Rollover Sensor																																																												
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																																												
ALL	2008	H2	Body	Theft Deterrent Module																																																												
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																																												

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)																																																													
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																													
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																													
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																													
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module																																																													
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																													
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																																													
ALL	2008	H3	Chassis	EBCM																																																														
ALL	2008	H3	Body	Body Control Module (5GT)																																																													
ALL	2008	H3	Body	Body Control Module (ADM)																																																													
ALL	2008	H3	Body	Digital Radio Receiver																																																													
ALL	2008	H3	Body	Generator Battery Control Module																																																													
ALL	2008	H3	Body	Instrument Panel Cluster																																																													
ALL	2008	H3	Body	Personal Audio Link Module																																																													
ALL	2008	H3	Body	Uplevel Radio																																																													
ALL	2008	H3	Body	Navigation Radio																																																													
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																																													
ALL	2008	H3	Body	Theft Deterrent Module																																																													
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																																													
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																								V																				
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																													
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																													
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																													
ALL	2009	H2	Chassis	Air SCM																																																														
ALL	2009	H2	Chassis	EBCM																																																													
ALL	2009	H2	Body	Amplifier (Bose)																																																													
ALL	2009	H2	Body	Body Control Module																																																													
ALL	2009	H2	Body	Digital Radio Receiver																																																													
ALL	2009	H2	Body	Driver Door Switch																																																													
ALL	2009	H2	Body	HVAC Control Module																																																													
ALL	2009	H2	Body	Instrument Panel Cluster																																																													
ALL	2009	H2	Body	Memory Seat Module																																																													
ALL	2009	H2	Body	Passenger Door Switch																																																													
ALL	2009	H2	Body	Radio																																																													
ALL	2009	H2	Body	Rear Heated Seat Module																																																													
ALL	2009	H2	Body	Rear HVAC/RSA																																																													
ALL	2009	H2	Body	Rollover Sensor																																																													
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																																													
ALL	2009	H2	Body	Theft Deterrent Module																																																													
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																													
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																													
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)																																																													
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																													
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																													
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																													
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																													
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																													
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)																																																													
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)																																																													
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																													
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																																													
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																																													
ALL	2009	H3	Chassis	EBCM																																																													
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																																													
ALL	2009	H3	Body	Body Control Module (ADM)																																																													
ALL	2009	H3	Body	Digital Radio Receiver																																																													
ALL	2009	H3	Body	Generator Battery Control Module																																																													
ALL	2009	H3	Body	Instrument Panel Cluster																																																													
ALL	2009	H3	Body	Personal Audio Link Module																																																													
ALL	2009	H3	Body	Uplevel Radio																																																													
ALL	2009	H3	Body	Navigation Radio																																																													
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																																													
ALL	2009	H3	Body	Theft Deterrent Module																																																													
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																																													
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																													
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																													
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																													
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																													
ALL	2010	H2	Chassis	Air SCM																																																														
ALL	2010	H2	Chassis	EBCM																																																													
ALL	2010	H2	Body	Amplifier (Bose)																																																													
ALL	2010	H2	Body	Body Control Module																																																													
ALL	2010	H2	Body	Digital Radio Receiver																																																													
ALL	2010	H2	Body	Driver Door Switch																																																													
ALL	2010	H2	Body	HVAC Control Module																																																													
ALL	2010	H2	Body	Instrument Panel Cluster																																																													
ALL	2010	H2	Body	Memory Seat Module																																																													
ALL	2010	H2	Body	Passenger Door Switch																																																													
ALL	2010	H2	Body	Personal Audio Link Module																																																													
ALL	2010	H2	Body	Radio																																																													
ALL	2010	H2	Body	Rear Heated Seat Module																																																													
ALL	2010	H2	Body	Rear HVAC/RSA																																																													
ALL	2010	H2	Body	Rollover Sensor																																																													
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																																													
ALL	2010	H2	Body	Theft Deterrent Module																																																													
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																																													
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																													
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																													
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																													
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																													
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																													
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module																																																													
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																													
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																																													
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																																													
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																																													
ALL	2010	H3	Chassis	EBCM																																																														
ALL	2010	H3	Body	Body Control Module																																																													
ALL	2010	H3	Body	Digital Radio Receiver																																																													
ALL	2010	H3	Body	Generator Battery Control Module																																																													
ALL	2010	H3	Body	Instrument Panel Cluster																																																													

Engine type	Year	Model	System 1	System 2	Hybrid/EV Battery Pack Data Reset	Brake Controls Offset Learn	Electronic Brake Control Module Learn	Battery Energy Control Module Data	Voltage Data 1	Voltage Data 2	Voltage Data 3	High Voltage Contactor Lockout Status Data	Manual Service Disconnect Fuse Life Reset	BCM Data	Configuration	Electrical Data	Horn Data	Park Brake Data	Cruise Disengagement 1	Cruise Disengagement 2	DSCC Setup (Japan Only)	Roof History Data	Trunk History Data	Folding Top Learn Procedure	Module and Display Data	Radio Data 1	Radio Data 2	Door and Trunk Switches	Fob Data	Cruise Inhibit Data	Cruise Disengagement 3	Cruise Disengagement 4	Brake Press. Sensor Calibration	Depressurize System	Pressurize System	Induction	HVAC Data	Keyless Data	EPM Data	Cassette Data	CD Data	Automatic Transmission	Manual Transmission	Keyless Data/Remote Start Data	Auto Transmission Data	Steering Pos. Sensor Calibration	Keyless/Remote Start Data	Fuel Composition Reset	Telematic Vehicle Localization and Immobilization Data	Self-Test Data	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Ring Learn	Turbocharger Learn	Flywheel Learn	Glow Plug Control Module Reset	Injector Flow Rate Programming
ALL	2010	H3	Body	Personal Audio Link Module																																																																
ALL	2010	H3	Body	Uplevel Radio																																																																
ALL	2010	H3	Body	Navigation Radio																																																																
ALL	2010	H3	Body	Supplemental Inflatable Restraint																																																																
ALL	2010	H3	Body	Theft Deterrent Module																																																																
ALL	2010	H3	Body	Vehicle Comm. Interface Module																																																																

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2004	ALL	Chassis	ESC																																																										
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																										
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2004	ALL	Body	Instrument Panel Cluster																																																										
C	2004	ALL	Body	OnStar																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2004	ALL	Body	Passenger Door Module																																																											
C	2004	ALL	Body	Passenger Presence System																																																											
C	2004	ALL	Body	Radio Base																																																											
C	2004	ALL	Body	Radio Uplevel																																																											
C	2004	ALL	Body	Radio Navigation																																																											
C	2004	ALL	Body	Rear Aux. Climate Module																																																												
C	2004	ALL	Body	Rear HVAC																																																												
C	2004	ALL	Body	Rear Seat Audio																																																												
C	2004	ALL	Body	Rear Seat Entertainment																																																												
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2004	ALL	Body	Vehicle Theft Deterrent																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																														V	V												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																														V	V												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																												
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
C	2005	ALL	Chassis	ESC																																																											
C	2005	ALL	Chassis	Rear Wheel Steering																																																												
C	2005	ALL	Chassis	Tire Pressure Monitor																																																												
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2005	ALL	Chassis	VSES																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2005	ALL	Body	Amplifier (Bose)																																																											
C	2005	ALL	Body	Body Control Module																																																											
C	2005	ALL	Body	CD Changer																																																											
C	2005	ALL	Body	Chime																																																											
C	2005	ALL	Body	Disc Player and Video Display																																																												
C	2005	ALL	Body	Driver Door Module																																																												
C	2005	ALL	Body	Driver Seat Module																																																												
C	2005	ALL	Body	Generator Battery Control Module																																																												
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																												
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																												
C	2005	ALL	Body	Instrument Panel Cluster																																																												
C	2005	ALL	Body	Passenger Door Module																																																												
C	2005	ALL	Body	Passenger Presence System																																																												
C	2005	ALL	Body	Base Radio																																																												
C	2005	ALL	Body	Uplevel Radio																																																												
C	2005	ALL	Body	Navigation Radio																																																												
C	2005	ALL	Body	Rear Aux. Climate Module																																																												
C	2005	ALL	Body	Rear HVAC																																																												
C	2005	ALL	Body	Rear Seat Audio																																																												
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																												
C	2005	ALL	Body	Vehicle Theft Deterrent																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																											
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																											
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																												
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
C	2006	ALL	Chassis	ESC																																																												
C	2006	ALL	Chassis	Tire Pressure Monitor																																																												
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2006	ALL	Chassis	VSES																																																												
C	2006	ALL	Body	Amplifier (Bose)																																																												
C	2006	ALL	Body	Body Control Module																																																												
C	2006	ALL	Body	CD Changer																																																												
C	2006	ALL	Body	Chime																																																												
C	2006	ALL	Body	Disc Player and Video Display																																																												
C	2006	ALL	Body	Driver Door Module																																																												
C	2006	ALL	Body	Driver Seat Module																																																												
C	2006	ALL	Body	Generator Battery Control Module																																																												
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																												
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
C	2006	ALL	Body	Instrument Panel Cluster																																																												
C	2006	ALL	Body	Passenger Door Module																																																												
C	2006	ALL	Body	Passenger Presence System																																																												
C	2006	ALL	Body	Base Radio																																																												
C	2006	ALL	Body	Uplevel Radio																																																												
C	2006	ALL	Body	Navigation Radio																																																												
C	2006	ALL	Body	Rear Aux. Climate Module																																																												
C	2006	ALL	Body	Rear HVAC																																																												
C	2006	ALL	Body	Rear Seat Audio																																																												
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2006	ALL	Body	Vehicle Theft Deterrent																																																												
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Sierra	Chassis	Electronic Suspension Control																																																										
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																										
C	2007	Sierra	Body	Amplifier (Bose)																																																										
C	2007	Sierra	Body	Body Control Module																																																										
C	2007	Sierra	Body	Body Control Module (aux.)																																																										
C	2007	Sierra	Body	Digital Radio Receiver																																																										
C	2007	Sierra	Body	Driver Door Switch																																																										
C	2007	Sierra	Body	HVAC Control Module Auto																																																										
C	2007	Sierra	Body	HVAC Control Module Manual																																																										
C	2007	Sierra	Body	Instrument Panel Cluster																																																										
C	2007	Sierra	Body	Memory Seat Module																																																										
C	2007	Sierra	Body	Park Assist Module																																																										
C	2007	Sierra	Body	Passenger Door Switch																																																										
C	2007	Sierra	Body	Passenger Presence System																																																										
C	2007	Sierra	Body	Radio																																																										
C	2007	Sierra	Body	Rear Heated Seat Module																																																										
C	2007	Sierra	Body	Rear HVAC/RSA																																																										
C	2007	Sierra	Body	Rollover Sensor																																																										
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2007	Sierra	Body	Theft Deterrent Module																																																										
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																										
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																										
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2007	Yukon	Chassis	Electronic Suspension Control																																																										
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																										
C	2007	Yukon	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2007	Yukon	Body	Assist Step Controller																																																											
C	2007	Yukon	Body	Body Control Module																																																												
C	2007	Yukon	Body	Body Control Module (aux.)																																																												
C	2007	Yukon	Body	Digital Radio Receiver																																																												
C	2007	Yukon	Body	Driver Door Switch																																																												
C	2007	Yukon	Body	HVAC Control Module Auto																																																												
C	2007	Yukon	Body	HVAC Control Module Manual																																																												
C	2007	Yukon	Body	Instrument Panel Cluster																																																												
C	2007	Yukon	Body	Lift Gate Module																																																												
C	2007	Yukon	Body	Memory Seat Module																																																												
C	2007	Yukon	Body	Park Assist Module																																																												
C	2007	Yukon	Body	Passenger Door Switch																																																												
C	2007	Yukon	Body	Passenger Presence System																																																												
C	2007	Yukon	Body	Radio																																																												
C	2007	Yukon	Body	Rear Heated Seat Module																																																												
C	2007	Yukon	Body	Rear HVAC/RSA																																																												
C	2007	Yukon	Body	Rollover Sensor																																																												
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																																												
C	2007	Yukon	Body	Theft Deterrent Module																																																												
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2007	Yukon XL	Body	Amplifier (Bose)																																																												
C	2007	Yukon XL	Body	Assist Step Controller																																																												
C	2007	Yukon XL	Body	Body Control Module																																																												
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2007	Yukon XL	Body	Digital Radio Receiver																																																												
C	2007	Yukon XL	Body	Driver Door Switch																																																												
C	2007	Yukon XL	Body	HVAC Control Module Auto																																																												
C	2007	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2007	Yukon XL	Body	Lift Gate Module																																																												
C	2007	Yukon XL	Body	Memory Seat Module																																																												
C	2007	Yukon XL	Body	Park Assist Module																																																												
C	2007	Yukon XL	Body	Passenger Door Switch																																																												
C	2007	Yukon XL	Body	Passenger Presence System																																																												
C	2007	Yukon XL	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2007	Yukon XL	Body	Rear Heated Seat Module																																																											
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2007	Yukon XL	Body	Rollover Sensor																																																												
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2007	Yukon XL	Body	Theft Deterrent Module																																																												
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Sierra	Chassis	Electronic Suspension Control																																																												
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2008	Sierra	Body	Amplifier (Bose)																																																												
C	2008	Sierra	Body	Body Control Module																																																												
C	2008	Sierra	Body	Body Control Module (aux.)																																																												
C	2008	Sierra	Body	Digital Radio Receiver																																																												
C	2008	Sierra	Body	Driver Door Switch																																																												
C	2008	Sierra	Body	HVAC Control Module Auto																																																												
C	2008	Sierra	Body	HVAC Control Module Manual																																																												
C	2008	Sierra	Body	Instrument Panel Cluster																																																												
C	2008	Sierra	Body	Memory Seat Module																																																												
C	2008	Sierra	Body	Park Assist Module																																																												
C	2008	Sierra	Body	Passenger Door Switch																																																												
C	2008	Sierra	Body	Passenger Presence System																																																												
C	2008	Sierra	Body	Radio																																																											
C	2008	Sierra	Body	Rear Heated Seat Module																																																												
C	2008	Sierra	Body	Rear HVAC/RSA																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2008	Sierra	Body	Rollover Sensor																																																											
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2008	Sierra	Body	Theft Deterrent Module																																																												
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Yukon	Chassis	Electronic Brake Control Module																																																												
C	2008	Yukon	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon	Body	Amplifier (Bose)																																																												
C	2008	Yukon	Body	Assist Step Controller																																																												
C	2008	Yukon	Body	Body Control Module																																																												
C	2008	Yukon	Body	Body Control Module (aux.)																																																												
C	2008	Yukon	Body	Digital Radio Receiver																																																												
C	2008	Yukon	Body	Driver Door Switch																																																												
C	2008	Yukon	Body	HVAC Control Module Auto																																																												
C	2008	Yukon	Body	HVAC Control Module Manual																																																												
C	2008	Yukon	Body	Instrument Panel Cluster																																																												
C	2008	Yukon	Body	Lift Gate Module																																																												
C	2008	Yukon	Body	Memory Seat Module																																																												
C	2008	Yukon	Body	Park Assist Module																																																												
C	2008	Yukon	Body	Passenger Door Switch																																																												
C	2008	Yukon	Body	Passenger Presence System																																																												
C	2008	Yukon	Body	Radio																																																											
C	2008	Yukon	Body	Rear Heated Seat Module																																																												
C	2008	Yukon	Body	Rear HVAC/RSA																																																												
C	2008	Yukon	Body	Rollover Sensor																																																												
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon	Body	Theft Deterrent Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																										
C	2008	Yukon Hybrid	Body	Body Control Module																																																										
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																										
C	2008	Yukon Hybrid	Body	HVAC Control Module																																																										
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2008	Yukon Hybrid	Body	Lift Gate Module																																																										
C	2008	Yukon Hybrid	Body	Memory Seat Module																																																										
C	2008	Yukon Hybrid	Body	Park Assist Module																																																										
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																										
C	2008	Yukon Hybrid	Body	Passenger Presence System																																																										
C	2008	Yukon Hybrid	Body	Radio																																																										
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																										
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																										
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon XL	Body	Amplifier (Bose)																																																										
C	2008	Yukon XL	Body	Assist Step Controller																																																										
C	2008	Yukon XL	Body	Body Control Module																																																										
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2008	Yukon XL	Body	Digital Radio Receiver																																																										
C	2008	Yukon XL	Body	Driver Door Switch																																																										
C	2008	Yukon XL	Body	HVAC Control Module Auto																																																										
C	2008	Yukon XL	Body	HVAC Control Module Manual																																																										
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2008	Yukon XL	Body	Lift Gate Module																																																										
C	2008	Yukon XL	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2008	Yukon XL	Body	Park Assist Module																																																											
C	2008	Yukon XL	Body	Passenger Door Switch																																																												
C	2008	Yukon XL	Body	Passenger Presence System																																																												
C	2008	Yukon XL	Body	Radio																																																												
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2008	Yukon XL	Body	Rollover Sensor																																																												
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon XL	Body	Theft Deterrent Module																																																												
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual																																																												
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2009	Sierra	Chassis	Electronic Suspension Control																																																												
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2009	Sierra	Body	Amplifier (Bose)																																																												
C	2009	Sierra	Body	Body Control Module																																																												
C	2009	Sierra	Body	Body Control Module (aux.)																																																												
C	2009	Sierra	Body	Digital Radio Receiver																																																												
C	2009	Sierra	Body	Driver Door Switch																																																												
C	2009	Sierra	Body	HVAC Control Module Auto																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2009	Sierra	Body	HVAC Control Module Manual																																																											
C	2009	Sierra	Body	Instrument Panel Cluster																																																												
C	2009	Sierra	Body	Memory Seat Module																																																												
C	2009	Sierra	Body	Park Assist Module																																																											
C	2009	Sierra	Body	Passenger Door Switch																																																											
C	2009	Sierra	Body	Passenger Presence System																																																											
C	2009	Sierra	Body	Radio																																																											
C	2009	Sierra	Body	Rear Heated Seat Module																																																												
C	2009	Sierra	Body	Rear HVAC/RSA																																																												
C	2009	Sierra	Body	Rollover Sensor																																																												
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2009	Sierra	Body	Theft Deterrent Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																												
C	2009	Sierra Hybrid	Body	Body Control Module																																																												
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																												
C	2009	Sierra Hybrid	Body	Driver Door Switch																																																												
C	2009	Sierra Hybrid	Body	HVAC Control Module																																																												
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
C	2009	Sierra Hybrid	Body	Memory Seat Module																																																												
C	2009	Sierra Hybrid	Body	Park Assist Module																																																												
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																																												
C	2009	Sierra Hybrid	Body	Passenger Presence System																																																												
C	2009	Sierra Hybrid	Body	Radio																																																												
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																												
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
C	2009	Yukon	Chassis	Electronic Brake Control Module																																																													
C	2009	Yukon	Chassis	Electronic Suspension Control																																																													
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																													
C	2009	Yukon	Body	Amplifier (Bose)																																																													
C	2009	Yukon	Body	Assist Step Controller																																																													
C	2009	Yukon	Body	Body Control Module																																																													
C	2009	Yukon	Body	Body Control Module (aux.)																																																													
C	2009	Yukon	Body	Digital Radio Receiver																																																													
C	2009	Yukon	Body	Driver Door Switch																																																													
C	2009	Yukon	Body	HVAC Control Module Auto																																																													
C	2009	Yukon	Body	HVAC Control Module Manual																																																													
C	2009	Yukon	Body	Instrument Panel Cluster																																																													
C	2009	Yukon	Body	Left Side Object Detection Module																																																													
C	2009	Yukon	Body	Lift Gate Module																																																													
C	2009	Yukon	Body	Memory Seat Module																																																													
C	2009	Yukon	Body	Park Assist Module																																																													
C	2009	Yukon	Body	Passenger Door Switch																																																													
C	2009	Yukon	Body	Passenger Presence System																																																													
C	2009	Yukon	Body	Radio																																																													
C	2009	Yukon	Body	Rear Heated Seat Module																																																													
C	2009	Yukon	Body	Rear HVAC/RSA																																																													
C	2009	Yukon	Body	Right Side Object Detection Module																																																													
C	2009	Yukon	Body	Rollover Sensor																																																													
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																																													
C	2009	Yukon	Body	Theft Deterrent Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																													
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																													
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																													
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																													
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																													
C	2009	Yukon Hybrid	Body	Body Control Module																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2009	Yukon Hybrid	Body	Driver Door Switch																																																										
C	2009	Yukon Hybrid	Body	Heated Seat Module																																																										
C	2009	Yukon Hybrid	Body	HVAC Control Module																																																										
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
C	2009	Yukon Hybrid	Body	Park Assist Module																																																										
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																																										
C	2009	Yukon Hybrid	Body	Passenger Presence System																																																										
C	2009	Yukon Hybrid	Body	Radio																																																										
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																										
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																										
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2009	Yukon XL	Body	Amplifier (Bose)																																																										
C	2009	Yukon XL	Body	Assist Step Controller																																																										
C	2009	Yukon XL	Body	Body Control Module																																																										
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2009	Yukon XL	Body	Digital Radio Receiver																																																										
C	2009	Yukon XL	Body	Driver Door Switch																																																										
C	2009	Yukon XL	Body	HVAC Control Module Auto																																																										
C	2009	Yukon XL	Body	HVAC Control Module Manual																																																										
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2009	Yukon XL	Body	Left Side Object Detection Module																																																										
C	2009	Yukon XL	Body	Lift Gate Module																																																										
C	2009	Yukon XL	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2009	Yukon XL	Body	Park Assist Module																																																											
C	2009	Yukon XL	Body	Passenger Door Switch																																																												
C	2009	Yukon XL	Body	Passenger Presence System																																																												
C	2009	Yukon XL	Body	Radio																																																												
C	2009	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2009	Yukon XL	Body	Right Side Object Detection Module																																																												
C	2009	Yukon XL	Body	Rollover Sensor																																																												
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2009	Yukon XL	Body	Theft Deterrent Module																																																												
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2010	Sierra	Chassis	Electronic Suspension Control																																																												
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra	Body	Amplifier (Bose)																																																												
C	2010	Sierra	Body	Body Control Module																																																												
C	2010	Sierra	Body	Body Control Module (aux.)																																																												
C	2010	Sierra	Body	Digital Radio Receiver																																																												
C	2010	Sierra	Body	Driver Door Switch																																																												
C	2010	Sierra	Body	HVAC Control Module Auto																																																												
C	2010	Sierra	Body	HVAC Control Module Manual																																																												
C	2010	Sierra	Body	Instrument Panel Cluster																																																												
C	2010	Sierra	Body	Memory Seat Module																																																												
C	2010	Sierra	Body	Park Assist Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2010	Sierra	Body	Passenger Door Switch																																																											
C	2010	Sierra	Body	Passenger Presence System																																																												
C	2010	Sierra	Body	Radio																																																												
C	2010	Sierra	Body	Rear Heated Seat Module																																																												
C	2010	Sierra	Body	Rear HVAC/RSA																																																												
C	2010	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2010	Sierra	Body	Theft Deterrent Module																																																												
C	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																												
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																												
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																												
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																												
C	2010	Sierra Hybrid	Body	Body Control Module																																																												
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																												
C	2010	Sierra Hybrid	Body	Driver Door Switch																																																												
C	2010	Sierra Hybrid	Body	Heated Seat Module																																																												
C	2010	Sierra Hybrid	Body	HVAC Control Module																																																												
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
C	2010	Sierra Hybrid	Body	Park Assist Module																																																												
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																																												
C	2010	Sierra Hybrid	Body	Passenger Presence System																																																												
C	2010	Sierra Hybrid	Body	Radio																																																												
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																												
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Yukon	Chassis	Electronic Brake Control Module																																																												
C	2010	Yukon	Chassis	Electronic Suspension Control																																																												
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon	Body	Amplifier (Bose)																																																												
C	2010	Yukon	Body	Assist Step Controller																																																												
C	2010	Yukon	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2010	Yukon	Body	Body Control Module (aux.)																																																											
C	2010	Yukon	Body	Digital Radio Receiver																																																												
C	2010	Yukon	Body	Driver Door Switch																																																												
C	2010	Yukon	Body	HVAC Control Module Auto																																																												
C	2010	Yukon	Body	HVAC Control Module Manual																																																												
C	2010	Yukon	Body	Instrument Panel Cluster																																																												
C	2010	Yukon	Body	Left Side Object Detection Module																																																												
C	2010	Yukon	Body	Lift Gate Module																																																												
C	2010	Yukon	Body	Memory Seat Module																																																												
C	2010	Yukon	Body	Park Assist Module																																																												
C	2010	Yukon	Body	Passenger Door Switch																																																												
C	2010	Yukon	Body	Passenger Presence System																																																												
C	2010	Yukon	Body	Radio																																																												
C	2010	Yukon	Body	Rear Heated Seat Module																																																												
C	2010	Yukon	Body	Rear HVAC/RSA																																																												
C	2010	Yukon	Body	Right Side Object Detection Module																																																												
C	2010	Yukon	Body	Supplemental Inflatable Restraint																																																												
C	2010	Yukon	Body	Theft Deterrent Module																																																												
C	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																												
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																												
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																												
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																												
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																												
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																												
C	2010	Yukon Hybrid	Body	Body Control Module																																																												
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																												
C	2010	Yukon Hybrid	Body	Driver Door Switch																																																												
C	2010	Yukon Hybrid	Body	Heated Seat Module																																																												
C	2010	Yukon Hybrid	Body	HVAC Control Module																																																												
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
C	2010	Yukon Hybrid	Body	Lift Gate Module																																																												
C	2010	Yukon Hybrid	Body	Park Assist Module																																																												
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																																												
C	2010	Yukon Hybrid	Body	Passenger Presence System																																																												
C	2010	Yukon Hybrid	Body	Radio																																																												
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																											
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																												
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																												
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2010	Yukon XL	Body	Amplifier (Bose)																																																												
C	2010	Yukon XL	Body	Assist Step Controller																																																												
C	2010	Yukon XL	Body	Body Control Module																																																												
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2010	Yukon XL	Body	Digital Radio Receiver																																																												
C	2010	Yukon XL	Body	Driver Door Switch																																																												
C	2010	Yukon XL	Body	HVAC Control Module Auto																																																												
C	2010	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2010	Yukon XL	Body	Left Side Object Detection Module																																																												
C	2010	Yukon XL	Body	Lift Gate Module																																																												
C	2010	Yukon XL	Body	Memory Seat Module																																																												
C	2010	Yukon XL	Body	Park Assist Module																																																												
C	2010	Yukon XL	Body	Passenger Door Switch																																																												
C	2010	Yukon XL	Body	Passenger Presence System																																																												
C	2010	Yukon XL	Body	Radio																																																												
C	2010	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2010	Yukon XL	Body	Right Side Object Detection Module																																																												
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2010	Yukon XL	Body	Theft Deterrent Module																																																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																												
D	2008	ALL	Chassis	Electronic Brake Control Module																																																												
D	2008	ALL	Body	Body Control Module																																																											
D	2008	ALL	Body	Body Control Module (aux.)																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
D	2008	ALL	Body	Headlamp Control Module																																																										
D	2008	ALL	Body	HVAC Control Module Auto																																																										
D	2008	ALL	Body	Instrument Panel Cluster																																																										
D	2008	ALL	Body	Park Assist Module																																																										
D	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
D	2008	ALL	Body	Theft Deterrent Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2009	ALL	Chassis	Electronic Brake Control Module																																																										
D	2009	ALL	Body	Body Control Module																																																										
D	2009	ALL	Body	Body Control Module (aux.)																																																										
D	2009	ALL	Body	Headlamp Control Module																																																										
D	2009	ALL	Body	HVAC Control Module Auto																																																										
D	2009	ALL	Body	Instrument Panel Cluster																																																										
D	2009	ALL	Body	Park Assist Module																																																										
D	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
D	2009	ALL	Body	Theft Deterrent Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2010	ALL	Chassis	Electronic Brake Control Module																																																										
D	2010	ALL	Body	Body Control Module																																																										
D	2010	ALL	Body	Body Control Module (aux.)																																																										
D	2010	ALL	Body	Headlamp Control Module																																																										
D	2010	ALL	Body	HVAC Control Module Auto																																																										
D	2010	ALL	Body	Instrument Panel Cluster																																																										
D	2010	ALL	Body	Park Assist Module																																																										
D	2010	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																												V	V													
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																												V	V													
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																										
G	2004	Express/Savana	Body	Body Control Module																																																										
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2004	Express/Savana	Body	OnStar																																																										
G	2004	Express/Savana	Body	Base Radio																																																										
G	2004	Express/Savana	Body	Uplevel Radio																																																										
G	2004	Express/Savana	Body	Remote Function Actuation																																																										
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																													V	V												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																													V	V												
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																																										
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2005	Express/Savana	Chassis	VSES																																																										
G	2005	Express/Savana	Body	Body Control Module																																																										
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2005	Express/Savana	Body	Base Radio																																																										
G	2005	Express/Savana	Body	Uplevel Radio																																																										
G	2005	Express/Savana	Body	Remote Function Actuation																																																										
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2005	Express Access/Savana Pro	Chassis	VSES																																																										
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2005	Express Access/Savana Pro	Body	Base Radio																																																										
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2006	Express/Savana	Chassis	VSES																																																										
G	2006	Express/Savana	Body	Body Control Module																																																										
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2006	Express/Savana	Body	Passenger Presence System																																																										
G	2006	Express/Savana	Body	Base Radio																																																										
G	2006	Express/Savana	Body	Uplevel Radio																																																										
G	2006	Express/Savana	Body	Remote Function Actuation																																																										
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2006	Express Access/Savana Pro	Chassis	VSES																																																										
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2006	Express Access/Savana Pro	Body	Base Radio																																																										
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express/Savana	Body	Body Control Module																																																										
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2007	Express/Savana	Body	Passenger Presence System																																																										
G	2007	Express/Savana	Body	Base Radio																																																										
G	2007	Express/Savana	Body	Uplevel Radio																																																										
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2007	Express Access/Savana Pro	Body	Radio																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express/Savana	Body	Body Control Module																																																										
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2008	Express/Savana	Body	Passenger Presence System																																																										
G	2008	Express/Savana	Body	Radio																																																										
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express/Savana	Body	Rollover Sensor																																																										
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2008	Express/Savana	Body	Theft Deterrent Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2008	Express Access/Savana Pro	Body	Radio																																																											
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2009	Express/Savana	Body	Body Control Module																																																											
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2009	Express/Savana	Body	Passenger Presence System																																																											
G	2009	Express/Savana	Body	Radio																																																											
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2009	Express/Savana	Body	Rollover Sensor																																																											
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2009	Express/Savana	Body	Theft Deterrent Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2009	Express Access/Savana Pro	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																													
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																													
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2010	Express/Savana	Body	Body Control Module																																																													
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2010	Express/Savana	Body	Passenger Presence System																																																													
G	2010	Express/Savana	Body	Radio																																																												
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
G	2010	Express/Savana	Body	Rollover Sensor																																																													
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
G	2010	Express/Savana	Body	Theft Deterrent Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2010	Express Access/Savana Pro	Body	Radio																																																										
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2004	Express/Savana	Chassis	VSES																																																										
H	2004	Express/Savana	Body	Body Control Module																																																										
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2004	Express/Savana	Body	OnStar																																																										
H	2004	Express/Savana	Body	Base Radio																																																										
H	2004	Express/Savana	Body	Uplevel Radio																																																										
H	2004	Express/Savana	Body	Remote Function Actuation																																																										
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2004	Express Access/Savana Pro	Chassis	VSES																																																										
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2004	Express Access/Savana Pro	Body	OnStar																																																										
H	2004	Express Access/Savana Pro	Body	Base Radio																																																										
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2005	Express/Savana	Chassis	VSES																																																										
H	2005	Express/Savana	Body	Body Control Module																																																										
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2005	Express/Savana	Body	Base Radio																																																										
H	2005	Express/Savana	Body	Uplevel Radio																																																										
H	2005	Express/Savana	Body	Remote Function Actuation																																																										
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2005	Express Access/Savana Pro	Chassis	VSES																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
H	2005	Express Access/Savana Pro	Body	Base Radio																																																											
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																											
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																											
H	2006	Express/Savana	Chassis	VSES																																																											
H	2006	Express/Savana	Body	Body Control Module																																																											
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2006	Express/Savana	Body	Passenger Presence System																																																											
H	2006	Express/Savana	Body	Base Radio																																																											
H	2006	Express/Savana	Body	Uplevel Radio																																																											
H	2006	Express/Savana	Body	Remote Function Actuation																																																											
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																											
H	2006	Express Access/Savana Pro	Chassis	VSES																																																											
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																											
H	2006	Express Access/Savana Pro	Body	Base Radio																																																											
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																											
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2007	Express/Savana	Body	Body Control Module																																																											
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2007	Express/Savana	Body	Passenger Presence System																																																											
H	2007	Express/Savana	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2007	Express/Savana	Body	Uplevel Radio																																																										
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2007	Express Access/Savana Pro	Body	Base Radio																																																										
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express/Savana	Body	Body Control Module																																																										
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2008	Express/Savana	Body	Passenger Presence System																																																										
H	2008	Express/Savana	Body	Radio																																																										
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express/Savana	Body	Rollover Sensor																																																										
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express/Savana	Body	Theft Deterrent Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module																																																										
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																																										
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express/Savana	Body	Theft Deterrent Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express/Savana	Body	Body Control Module																																																										
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2010	Express/Savana	Body	Passenger Presence System																																																										
H	2010	Express/Savana	Body	Radio																																																										
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express/Savana	Body	Rollover Sensor																																																										
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express/Savana	Body	Theft Deterrent Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2010	Express Access/Savana Pro	Body	Radio																																																										
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																												V	V													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																												V	V													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																													
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																													
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																													
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																													
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																													
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																													
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																													
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																													
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																													
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																													
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																													
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																													
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																													
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																													
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																													
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																													
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																													
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																													
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																													
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																													
K	2004	ALL	Chassis	ESC																																																													
K	2004	ALL	Chassis	Rear Wheel Steering																																																													
K	2004	ALL	Chassis	Tire Pressure Monitor																																																													
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																													
K	2004	ALL	Chassis	VSES																																																													
K	2004	ALL	Body	Amplifier (Bose)																																																													
K	2004	ALL	Body	Body Control Module																																																													
K	2004	ALL	Body	CD Changer																																																													
K	2004	ALL	Body	Chime																																																													
K	2004	ALL	Body	Driver Door Module																																																													
K	2004	ALL	Body	Driver Seat Module																																																													
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																													
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																													
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																													
K	2004	ALL	Body	Instrument Panel Cluster																																																													
K	2004	ALL	Body	OnStar																																																													
K	2004	ALL	Body	Passenger Door Module																																																													
K	2004	ALL	Body	Passenger Presence System																																																													
K	2004	ALL	Body	Radio Base																																																													
K	2004	ALL	Body	Radio Uplevel																																																													
K	2004	ALL	Body	Radio Navigation																																																													
K	2004	ALL	Body	Rear Aux. Climate Module																																																													
K	2004	ALL	Body	Rear HVAC																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2004	ALL	Body	Rear Seat Audio																																																											
K	2004	ALL	Body	Rear Seat Entertainment																																																												
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2004	ALL	Body	Vehicle Theft Deterrent																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																												
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																												
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																												
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																												
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																												
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																												
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																												
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																												
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																												
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																												
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2005	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
K	2006	ALL	Chassis	ESC																																																											
K	2006	ALL	Chassis	Tire Pressure Monitor																																																											
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																											
K	2006	ALL	Chassis	VSES																																																										
K	2006	ALL	Body	Amplifier (Bose)																																																											
K	2006	ALL	Body	Body Control Module																																																											
K	2006	ALL	Body	CD Changer																																																											
K	2006	ALL	Body	Chime																																																											
K	2006	ALL	Body	Disc Player and Video Display																																																												
K	2006	ALL	Body	Driver Door Module																																																											
K	2006	ALL	Body	Driver Seat Module																																																											
K	2006	ALL	Body	Generator Battery Control Module																																																											
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2006	ALL	Body	Instrument Panel Cluster																																																												
K	2006	ALL	Body	Passenger Door Module																																																												
K	2006	ALL	Body	Passenger Presence System																																																												
K	2006	ALL	Body	Base Radio																																																												
K	2006	ALL	Body	Uplevel Radio																																																												
K	2006	ALL	Body	Navigation Radio																																																												
K	2006	ALL	Body	Rear Aux. Climate Module																																																												
K	2006	ALL	Body	Rear HVAC																																																												
K	2006	ALL	Body	Rear Seat Audio																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2006	ALL	Body	Vehicle Theft Deterrent																																																												
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Sierra	Chassis	Electronic Suspension Control																																																												
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																												
K	2007	Sierra	Body	Amplifier (Bose)																																																												
K	2007	Sierra	Body	Body Control Module																																																												
K	2007	Sierra	Body	Body Control Module (aux.)																																																												
K	2007	Sierra	Body	Digital Radio Receiver																																																												
K	2007	Sierra	Body	Driver Door Switch																																																												
K	2007	Sierra	Body	HVAC Control Module Auto																																																												
K	2007	Sierra	Body	HVAC Control Module Manual																																																												
K	2007	Sierra	Body	Instrument Panel Cluster																																																												
K	2007	Sierra	Body	Memory Seat Module																																																												
K	2007	Sierra	Body	Park Assist Module																																																												
K	2007	Sierra	Body	Passenger Door Switch																																																												
K	2007	Sierra	Body	Passenger Presence System																																																												
K	2007	Sierra	Body	Radio																																																												
K	2007	Sierra	Body	Rear Heated Seat Module																																																												
K	2007	Sierra	Body	Rear HVAC/RSA																																																												
K	2007	Sierra	Body	Rollover Sensor																																																												
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																																												
K	2007	Sierra	Body	Theft Deterrent Module																																																												
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Yukon	Chassis	Electronic Suspension Control																																																												
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																												
K	2007	Yukon	Body	Amplifier (Bose)																																																												
K	2007	Yukon	Body	Assist Step Controller																																																												
K	2007	Yukon	Body	Body Control Module																																																												
K	2007	Yukon	Body	Body Control Module (aux.)																																																												
K	2007	Yukon	Body	Digital Radio Receiver																																																												
K	2007	Yukon	Body	Driver Door Switch																																																												
K	2007	Yukon	Body	HVAC Control Module Auto																																																												
K	2007	Yukon	Body	HVAC Control Module Manual																																																												
K	2007	Yukon	Body	Instrument Panel Cluster																																																												
K	2007	Yukon	Body	Lift Gate Module																																																												
K	2007	Yukon	Body	Memory Seat Module																																																												
K	2007	Yukon	Body	Park Assist Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2007	Yukon	Body	Passenger Door Switch																																																											
K	2007	Yukon	Body	Passenger Presence System																																																											
K	2007	Yukon	Body	Radio																																																											
K	2007	Yukon	Body	Rear Heated Seat Module																																																											
K	2007	Yukon	Body	Rear HVAC/RSA																																																											
K	2007	Yukon	Body	Rollover Sensor																																																											
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																																											
K	2007	Yukon	Body	Theft Deterrent Module																																																											
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																											
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																											
K	2007	Yukon XL	Body	Amplifier (Bose)																																																											
K	2007	Yukon XL	Body	Assist Step Controller																																																											
K	2007	Yukon XL	Body	Body Control Module																																																											
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																											
K	2007	Yukon XL	Body	Digital Radio Receiver																																																											
K	2007	Yukon XL	Body	Driver Door Switch																																																											
K	2007	Yukon XL	Body	HVAC Control Module Auto																																																											
K	2007	Yukon XL	Body	HVAC Control Module Manual																																																											
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																											
K	2007	Yukon XL	Body	Lift Gate Module																																																											
K	2007	Yukon XL	Body	Memory Seat Module																																																											
K	2007	Yukon XL	Body	Park Assist Module																																																											
K	2007	Yukon XL	Body	Passenger Door Switch																																																											
K	2007	Yukon XL	Body	Passenger Presence System																																																											
K	2007	Yukon XL	Body	Radio																																																										
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																											
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																											
K	2007	Yukon XL	Body	Rollover Sensor																																																											
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
K	2007	Yukon XL	Body	Theft Deterrent Module																																																											
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Sierra	Chassis	Electronic Suspension Control																																																										
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2008	Sierra	Body	Amplifier (Bose)																																																										
K	2008	Sierra	Body	Body Control Module																																																										
K	2008	Sierra	Body	Body Control Module (aux.)																																																										
K	2008	Sierra	Body	Digital Radio Receiver																																																										
K	2008	Sierra	Body	Driver Door Switch																																																										
K	2008	Sierra	Body	HVAC Control Module Auto																																																										
K	2008	Sierra	Body	HVAC Control Module Manual																																																										
K	2008	Sierra	Body	Instrument Panel Cluster																																																										
K	2008	Sierra	Body	Memory Seat Module																																																										
K	2008	Sierra	Body	Park Assist Module																																																										
K	2008	Sierra	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2008	Sierra	Body	Passenger Presence System																																																											
K	2008	Sierra	Body	Radio																																																											
K	2008	Sierra	Body	Rear Heated Seat Module																																																												
K	2008	Sierra	Body	Rear HVAC/RSA																																																												
K	2008	Sierra	Body	Rollover Sensor																																																												
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																																												
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																												
K	2008	Sierra	Body	Theft Deterrent Module																																																												
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2008	Yukon	Chassis	Electronic Brake Control Module																																																												
K	2008	Yukon	Chassis	Electronic Suspension Control																																																												
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																												
K	2008	Yukon	Body	Amplifier (Bose)																																																												
K	2008	Yukon	Body	Assist Step Controller																																																												
K	2008	Yukon	Body	Body Control Module																																																												
K	2008	Yukon	Body	Body Control Module (aux.)																																																												
K	2008	Yukon	Body	Digital Radio Receiver																																																												
K	2008	Yukon	Body	Driver Door Switch																																																												
K	2008	Yukon	Body	HVAC Control Module Auto																																																												
K	2008	Yukon	Body	HVAC Control Module Manual																																																												
K	2008	Yukon	Body	Instrument Panel Cluster																																																												
K	2008	Yukon	Body	Lift Gate Module																																																												
K	2008	Yukon	Body	Memory Seat Module																																																												
K	2008	Yukon	Body	Park Assist Module																																																												
K	2008	Yukon	Body	Passenger Door Switch																																																												
K	2008	Yukon	Body	Passenger Presence System																																																												
K	2008	Yukon	Body	Radio																																																												
K	2008	Yukon	Body	Rear Heated Seat Module																																																												
K	2008	Yukon	Body	Rear HVAC/RSA																																																												
K	2008	Yukon	Body	Rollover Sensor																																																												
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																																												
K	2008	Yukon	Body	Theft Deterrent Module																																																												
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																												
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																												
K	2008	Yukon Hybrid	Body	Body Control Module																																																												
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																												
K	2008	Yukon Hybrid	Body	Driver Door Switch																																																												
K	2008	Yukon Hybrid	Body	HVAC Control Module																																																												
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
K	2008	Yukon Hybrid	Body	Lift Gate Module																																																												
K	2008	Yukon Hybrid	Body	Memory Seat Module																																																												
K	2008	Yukon Hybrid	Body	Park Assist Module																																																												
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																																												
K	2008	Yukon Hybrid	Body	Passenger Presence System																																																												
K	2008	Yukon Hybrid	Body	Radio																																																												
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																												
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																												
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2008	Yukon XL	Body	Amplifier (Bose)																																																										
K	2008	Yukon XL	Body	Assist Step Controller																																																										
K	2008	Yukon XL	Body	Body Control Module																																																										
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2008	Yukon XL	Body	Digital Radio Receiver																																																										
K	2008	Yukon XL	Body	Driver Door Switch																																																										
K	2008	Yukon XL	Body	HVAC Control Module Auto																																																										
K	2008	Yukon XL	Body	HVAC Control Module Manual																																																										
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2008	Yukon XL	Body	Lift Gate Module																																																										
K	2008	Yukon XL	Body	Memory Seat Module																																																										
K	2008	Yukon XL	Body	Park Assist Module																																																										
K	2008	Yukon XL	Body	Passenger Door Switch																																																										
K	2008	Yukon XL	Body	Passenger Presence System																																																										
K	2008	Yukon XL	Body	Radio																																																										
K	2008	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2008	Yukon XL	Body	Rollover Sensor																																																										
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2008	Yukon XL	Body	Theft Deterrent Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2009	Sierra	Chassis	Electronic Suspension Control																																																										
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2009	Sierra	Body	Amplifier (Bose)																																																										
K	2009	Sierra	Body	Body Control Module																																																										
K	2009	Sierra	Body	Body Control Module (aux.)																																																										
K	2009	Sierra	Body	Digital Radio Receiver																																																										
K	2009	Sierra	Body	Driver Door Switch																																																										
K	2009	Sierra	Body	HVAC Control Module Auto																																																										
K	2009	Sierra	Body	HVAC Control Module Manual																																																										
K	2009	Sierra	Body	Instrument Panel Cluster																																																										
K	2009	Sierra	Body	Memory Seat Module																																																										
K	2009	Sierra	Body	Park Assist Module																																																										
K	2009	Sierra	Body	Passenger Door Switch																																																										
K	2009	Sierra	Body	Passenger Presence System																																																										
K	2009	Sierra	Body	Radio																																																										
K	2009	Sierra	Body	Rear Heated Seat Module																																																										
K	2009	Sierra	Body	Rear HVAC/RSA																																																										
K	2009	Sierra	Body	Rollover Sensor																																																										
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2009	Sierra	Body	Theft Deterrent Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2009	Sierra Hybrid	Body	Amplifier (Bose)
K	2009	Sierra Hybrid	Body	Body Control Module
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)
K	2009	Sierra Hybrid	Body	Digital Radio Receiver
K	2009	Sierra Hybrid	Body	Driver Door Switch
K	2009	Sierra Hybrid	Body	HVAC Control Module
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster
K	2009	Sierra Hybrid	Body	Memory Seat Module
K	2009	Sierra Hybrid	Body	Park Assist Module
K	2009	Sierra Hybrid	Body	Passenger Door Switch
K	2009	Sierra Hybrid	Body	Passenger Presence System
K	2009	Sierra Hybrid	Body	Radio
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA
K	2009	Sierra Hybrid	Body	Rollover Sensor
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint
K	2009	Sierra Hybrid	Body	Theft Deterrent Module
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module
K	2009	Yukon	Chassis	Electronic Brake Control Module
K	2009	Yukon	Chassis	Electronic Suspension Control
K	2009	Yukon	Chassis	Trailer Brake Control Module
K	2009	Yukon	Body	Amplifier (Bose)
K	2009	Yukon	Body	Assist Step Controller
K	2009	Yukon	Body	Body Control Module
K	2009	Yukon	Body	Body Control Module (aux.)
K	2009	Yukon	Body	Digital Radio Receiver
K	2009	Yukon	Body	Driver Door Switch
K	2009	Yukon	Body	HVAC Control Module Auto
K	2009	Yukon	Body	HVAC Control Module Manual

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2009	Yukon	Body	Instrument Panel Cluster																																																											
K	2009	Yukon	Body	Left Side Object Detection Module																																																												
K	2009	Yukon	Body	Lift Gate Module																																																												
K	2009	Yukon	Body	Memory Seat Module																																																												
K	2009	Yukon	Body	Park Assist Module																																																												
K	2009	Yukon	Body	Passenger Door Switch																																																												
K	2009	Yukon	Body	Passenger Presence System																																																												
K	2009	Yukon	Body	Radio																																																												
K	2009	Yukon	Body	Rear Heated Seat Module																																																												
K	2009	Yukon	Body	Rear HVAC/RSA																																																												
K	2009	Yukon	Body	Right Side Object Detection Module																																																												
K	2009	Yukon	Body	Rollover Sensor																																																												
K	2009	Yukon	Body	Supplemental Inflatable Restraint																																																												
K	2009	Yukon	Body	Theft Deterrent Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																												
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																												
K	2009	Yukon Hybrid	Body	Body Control Module																																																												
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Yukon Hybrid	Body	Driver Door Switch																																																												
K	2009	Yukon Hybrid	Body	Heated Seat Module																																																												
K	2009	Yukon Hybrid	Body	HVAC Control Module																																																												
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
K	2009	Yukon Hybrid	Body	Park Assist Module																																																												
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																																												
K	2009	Yukon Hybrid	Body	Passenger Presence System																																																												
K	2009	Yukon Hybrid	Body	Radio																																																												
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
K	2009	Yukon Hybrid	Body	Rollover Sensor																																																												
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																												
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2009	Yukon XL	Body	Amplifier (Bose)																																																										
K	2009	Yukon XL	Body	Assist Step Controller																																																										
K	2009	Yukon XL	Body	Body Control Module																																																										
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2009	Yukon XL	Body	Digital Radio Receiver																																																										
K	2009	Yukon XL	Body	Driver Door Switch																																																										
K	2009	Yukon XL	Body	HVAC Control Module Auto																																																										
K	2009	Yukon XL	Body	HVAC Control Module Manual																																																										
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2009	Yukon XL	Body	Left Side Object Detection Module																																																										
K	2009	Yukon XL	Body	Lift Gate Module																																																										
K	2009	Yukon XL	Body	Memory Seat Module																																																										
K	2009	Yukon XL	Body	Park Assist Module																																																										
K	2009	Yukon XL	Body	Passenger Door Switch																																																										
K	2009	Yukon XL	Body	Passenger Presence System																																																										
K	2009	Yukon XL	Body	Radio																																																										
K	2009	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2009	Yukon XL	Body	Right Side Object Detection Module																																																										
K	2009	Yukon XL	Body	Rollover Sensor																																																										
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2009	Yukon XL	Body	Theft Deterrent Module																																																										
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																										
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2010	Sierra	Chassis	Electronic Suspension Control																																																												
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																												
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra	Body	Amplifier (Bose)																																																												
K	2010	Sierra	Body	Body Control Module																																																											
K	2010	Sierra	Body	Body Control Module (aux.)																																																											
K	2010	Sierra	Body	Digital Radio Receiver																																																											
K	2010	Sierra	Body	Driver Door Switch																																																											
K	2010	Sierra	Body	HVAC Control Module Auto																																																											
K	2010	Sierra	Body	HVAC Control Module Manual																																																											
K	2010	Sierra	Body	Instrument Panel Cluster																																																											
K	2010	Sierra	Body	Memory Seat Module																																																											
K	2010	Sierra	Body	Park Assist Module																																																											
K	2010	Sierra	Body	Passenger Door Switch																																																											
K	2010	Sierra	Body	Passenger Presence System																																																											
K	2010	Sierra	Body	Radio																																																											
K	2010	Sierra	Body	Rear Heated Seat Module																																																											
K	2010	Sierra	Body	Rear HVAC/RSA																																																											
K	2010	Sierra	Body	Supplemental Inflatable Restraint																																																											
K	2010	Sierra	Body	Theft Deterrent Module																																																											
K	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																											
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Sierra Hybrid	Body	Body Control Module																																																										
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Sierra Hybrid	Body	Driver Door Switch																																																										
K	2010	Sierra Hybrid	Body	Heated Seat Module																																																										
K	2010	Sierra Hybrid	Body	HVAC Control Module																																																										
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Sierra Hybrid	Body	Park Assist Module																																																										
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																																										
K	2010	Sierra Hybrid	Body	Passenger Presence System																																																										
K	2010	Sierra Hybrid	Body	Radio																																																										
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon	Chassis	Electronic Brake Control Module																																																										
K	2010	Yukon	Chassis	Electronic Suspension Control																																																										
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon	Body	Amplifier (Bose)																																																										
K	2010	Yukon	Body	Assist Step Controller																																																										
K	2010	Yukon	Body	Body Control Module																																																										
K	2010	Yukon	Body	Body Control Module (aux.)																																																										
K	2010	Yukon	Body	Digital Radio Receiver																																																										
K	2010	Yukon	Body	Driver Door Switch																																																										
K	2010	Yukon	Body	HVAC Control Module Auto																																																										
K	2010	Yukon	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2010	Yukon	Body	Instrument Panel Cluster																																																											
K	2010	Yukon	Body	Left Side Object Detection Module																																																												
K	2010	Yukon	Body	Lift Gate Module																																																												
K	2010	Yukon	Body	Memory Seat Module																																																												
K	2010	Yukon	Body	Park Assist Module																																																												
K	2010	Yukon	Body	Passenger Door Switch																																																												
K	2010	Yukon	Body	Passenger Presence System																																																												
K	2010	Yukon	Body	Radio																																																												
K	2010	Yukon	Body	Rear Heated Seat Module																																																												
K	2010	Yukon	Body	Rear HVAC/RSA																																																												
K	2010	Yukon	Body	Right Side Object Detection Module																																																												
K	2010	Yukon	Body	Supplemental Inflatable Restraint																																																												
K	2010	Yukon	Body	Theft Deterrent Module																																																												
K	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																												
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																												
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																												
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																												
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Yukon Hybrid	Body	Body Control Module																																																												
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																												
K	2010	Yukon Hybrid	Body	Driver Door Switch																																																												
K	2010	Yukon Hybrid	Body	Heated Seat Module																																																												
K	2010	Yukon Hybrid	Body	HVAC Control Module																																																												
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
K	2010	Yukon Hybrid	Body	Lift Gate Module																																																												
K	2010	Yukon Hybrid	Body	Park Assist Module																																																												
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																																												
K	2010	Yukon Hybrid	Body	Passenger Presence System																																																												
K	2010	Yukon Hybrid	Body	Radio																																																												
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																												
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																												
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																												
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																												
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																												
K	2010	Yukon XL	Body	Amplifier (Bose)																																																												
K	2010	Yukon XL	Body	Assist Step Controller																																																												
K	2010	Yukon XL	Body	Body Control Module																																																												
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																												
K	2010	Yukon XL	Body	Digital Radio Receiver																																																												
K	2010	Yukon XL	Body	Driver Door Switch																																																												
K	2010	Yukon XL	Body	HVAC Control Module Auto																																																												
K	2010	Yukon XL	Body	HVAC Control Module Manual																																																												
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																												
K	2010	Yukon XL	Body	Left Side Object Detection Module																																																												
K	2010	Yukon XL	Body	Lift Gate Module																																																												
K	2010	Yukon XL	Body	Memory Seat Module																																																												
K	2010	Yukon XL	Body	Park Assist Module																																																												
K	2010	Yukon XL	Body	Passenger Door Switch																																																												
K	2010	Yukon XL	Body	Passenger Presence System																																																												
K	2010	Yukon XL	Body	Radio																																																												
K	2010	Yukon XL	Body	Rear Heated Seat Module																																																												
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																												
K	2010	Yukon XL	Body	Right Side Object Detection Module																																																												
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
K	2010	Yukon XL	Body	Theft Deterrent Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
L	2004	ALL	Chassis	4WAL 3 Sensor																																																												
L	2004	ALL	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2004	ALL	Body	Instrument Panel Cluster																																																											
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
L	2005	ALL	Chassis	4WAL 3 Sensor																																																												
L	2005	ALL	Body	Body Control Module																																																												
L	2005	ALL	Body	Instrument Panel Cluster																																																												
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																												
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																												
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																												
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																												
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																												
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2010	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2010	Terrain	Body	Body Control Module																																																												
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2010	Terrain	Body	Passenger Presence Module																																																												
L	2010	Terrain	Body	Instrument Cluster																																																												
L	2010	Terrain	Body	Radio																																																											
L	2010	Terrain	Body	Multimedia Player Interface Module																																																											
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																																											
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2010	Terrain	Body	Liftgate Control Module																																																											
L	2010	Terrain	Body	Parking Assist Control Module																																																											
L	2010	Terrain	Body	Frontview Camera Module																																																											
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																					V																																						
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																																											
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																											
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																											
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2011	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2011	Terrain	Body	Body Control Module																																																											
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2011	Terrain	Body	Passenger Presence Module																																																											
L	2011	Terrain	Body	Instrument Cluster																																																											
L	2011	Terrain	Body	Radio																																																											
L	2011	Terrain	Body	Multimedia Player Interface Module																																																											
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2011	Terrain	Body	Liftgate Control Module																																																												
L	2011	Terrain	Body	Parking Assist Control Module																																																												
L	2011	Terrain	Body	Frontview Camera Module																																																												
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																					V																																								
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																												
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2012	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2012	Terrain	Body	Body Control Module																																																												
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2012	Terrain	Body	Passenger Presence Module																																																												
L	2012	Terrain	Body	Instrument Cluster																																																												
L	2012	Terrain	Body	Radio																																																												
L	2012	Terrain	Body	Multimedia Player Interface Module																																																												
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2012	Terrain	Body	Liftgate Control Module																																																												
L	2012	Terrain	Body	Parking Assist Control Module																																																												
L	2012	Terrain	Body	Frontview Camera Module																																																												
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																					V																																								
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2013	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2013	Terrain	Chassis	Power Steering Control Module																																																												
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																																												
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2013	Terrain	Body	Passenger Presence Module																																																												
L	2013	Terrain	Body	Instrument Cluster																																																												
L	2013	Terrain	Body	Radio																																																												
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2013	Terrain	Body	Liftgate Control Module																																																												
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																												
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																												
L	2013	Terrain	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2013	Terrain	Body	Frontview Camera Module																																																											
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2014	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2014	Terrain	Chassis	Power Steering Control Module																																																												
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																																												
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2014	Terrain	Body	Passenger Presence Module																																																												
L	2014	Terrain	Body	Instrument Cluster																																																												
L	2014	Terrain	Body	Radio																																																											
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2014	Terrain	Body	Liftgate Control Module																																																											
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2014	Terrain	Body	Parking Assist Control Module																																																											
L	2014	Terrain	Body	Frontview Camera Module																																																											
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2015	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2015	Terrain	Chassis	Power Steering Control Module																																																											
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																																											
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2015	Terrain	Body	Passenger Presence Module																																																											
L	2015	Terrain	Body	Instrument Cluster																																																											
L	2015	Terrain	Body	Radio																																																											
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																																											
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2015	Terrain	Body	Liftgate Control Module																																																											
L	2015	Terrain	Body	Seat Memory Control Module																																																											
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2015	Terrain	Body	Parking Assist Control Module																																																											
L	2015	Terrain	Body	Frontview Camera Module																																																											
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2016	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2016	Terrain	Chassis	Power Steering Control Module																																																											
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																																											
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2016	Terrain	Body	Passenger Presence Module																																																											
L	2016	Terrain	Body	Instrument Cluster																																																											
L	2016	Terrain	Body	Radio																																																											
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																																											
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2016	Terrain	Body	Liftgate Control Module																																																											
L	2016	Terrain	Body	Seat Memory Control Module																																																											
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2016	Terrain	Body	Parking Assist Control Module																																																											
L	2016	Terrain	Body	Frontview Camera Module																																																											
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
M	2004	ALL	Chassis	4WAL 3 Sensor																																																											
M	2004	ALL	Body	Body Control Module																																																											
M	2004	ALL	Body	Instrument Panel Cluster																																																											
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
M	2005	ALL	Chassis	4WAL 3 Sensor																																																											
M	2005	ALL	Body	Body Control Module																																																											
M	2005	ALL	Body	Instrument Panel Cluster																																																											
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
P	2007	ALL	Body	Theft Deterrent Module																																																											
R	2007	ALL	Powertrain	Engine Control Module																																																											
R	2007	ALL	Powertrain	Transmission Control Module																																																											
R	2007	ALL	Chassis	Electronic Brake Control Module																																																											
R	2007	ALL	Body	Body Control Module																																																											
R	2007	ALL	Body	Digital Radio Receiver																																																											
R	2007	ALL	Body	Driver Door Switch																																																											
R	2007	ALL	Body	Head Up Display																																																											
R	2007	ALL	Body	Heated Seat Module																																																											
R	2007	ALL	Body	HVAC Control Module Auto																																																											
R	2007	ALL	Body	HVAC Control Module Manual																																																											
R	2007	ALL	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2007	ALL	Body	Lift Gate Module																																																											
R	2007	ALL	Body	Park Assist Module																																																											
R	2007	ALL	Body	Passenger Door Switch																																																											
R	2007	ALL	Body	Passenger Presence System																																																											
R	2007	ALL	Body	Radio																																																											
R	2007	ALL	Body	Rear HVAC/RSA																																																											
R	2007	ALL	Body	Rollover Sensor																																																											
R	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2007	ALL	Body	Theft Deterrent Module																																																											
R	2008	ALL	Powertrain	Engine Control Module																																																											
R	2008	ALL	Powertrain	Transmission Control Module																																																											
R	2008	ALL	Chassis	Electronic Brake Control Module																																																											
R	2008	ALL	Body	Body Control Module																																																											
R	2008	ALL	Body	Digital Radio Receiver																																																											
R	2008	ALL	Body	Driver Door Switch																																																											
R	2008	ALL	Body	Head Up Display																																																											
R	2008	ALL	Body	Heated Seat Module																																																											
R	2008	ALL	Body	HVAC Control Module Auto																																																											
R	2008	ALL	Body	HVAC Control Module Manual																																																											
R	2008	ALL	Body	Instrument Panel Cluster																																																											
R	2008	ALL	Body	Lift Gate Module																																																											
R	2008	ALL	Body	Park Assist Module																																																											
R	2008	ALL	Body	Passenger Door Switch																																																											
R	2008	ALL	Body	Passenger Presence System																																																											
R	2008	ALL	Body	Radio																																																											
R	2008	ALL	Body	Rear HVAC/RSA																																																											
R	2008	ALL	Body	Rollover Sensor																																																											
R	2008	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2008	ALL	Body	Theft Deterrent Module																																																											
R	2009	ALL	Powertrain	Engine Control Module																																																											
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2009	ALL	Powertrain	Transmission Control Module																																																											
R	2009	ALL	Chassis	Electronic Brake Control Module																																																											
R	2009	ALL	Body	Body Control Module																																																											
R	2009	ALL	Body	Digital Radio Receiver																																																											
R	2009	ALL	Body	Driver Door Switch																																																											
R	2009	ALL	Body	Head Up Display																																																											
R	2009	ALL	Body	Heated Seat Module																																																											
R	2009	ALL	Body	HVAC Control Module Auto																																																											
R	2009	ALL	Body	HVAC Control Module Manual																																																											
R	2009	ALL	Body	Instrument Panel Cluster																																																											
R	2009	ALL	Body	Lift Gate Module																																																											
R	2009	ALL	Body	Park Assist Module																																																											
R	2009	ALL	Body	Passenger Door Switch																																																											
R	2009	ALL	Body	Passenger Presence System																																																											
R	2009	ALL	Body	Radio																																																											
R	2009	ALL	Body	Rear HVAC/RSA																																																											
R	2009	ALL	Body	Rollover Sensor																																																											
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2009	ALL	Body	Theft Deterrent Module																																																											
R	2010	ALL	Powertrain	Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2010	ALL	Powertrain	Transmission Control Module																																																												
R	2010	ALL	Chassis	Electronic Brake Control Module																																																												
R	2010	ALL	Body	Body Control Module																																																												
R	2010	ALL	Body	Digital Radio Receiver																																																												
R	2010	ALL	Body	Driver Door Switch																																																												
R	2010	ALL	Body	Head Up Display																																																												
R	2010	ALL	Body	Heated Seat Module																																																												
R	2010	ALL	Body	HVAC Control Module Auto																																																												
R	2010	ALL	Body	HVAC Control Module Manual																																																												
R	2010	ALL	Body	Instrument Panel Cluster																																																												
R	2010	ALL	Body	Lift Gate Module																																																												
R	2010	ALL	Body	Park Assist Module																																																												
R	2010	ALL	Body	Passenger Door Switch																																																												
R	2010	ALL	Body	Passenger Presence System																																																												
R	2010	ALL	Body	Radio																																																												
R	2010	ALL	Body	Rear HVAC/RSA																																																												
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2010	ALL	Body	Theft Deterrent Module																																																												
R	2011	ALL	Powertrain	Engine Control Module																																																												
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2011	ALL	Powertrain	Transmission Control Module																																																												
R	2011	ALL	Chassis	Electronic Brake Control Module																																																												
R	2011	ALL	Body	Body Control Module																																																												
R	2011	ALL	Body	Digital Radio Receiver																																																												
R	2011	ALL	Body	Driver Door Switch																																																												
R	2011	ALL	Body	Head Up Display																																																												
R	2011	ALL	Body	Heated Seat Module																																																												
R	2011	ALL	Body	HVAC Control Module Auto																																																												
R	2011	ALL	Body	HVAC Control Module Manual																																																												
R	2011	ALL	Body	Instrument Panel Cluster																																																												
R	2011	ALL	Body	Lift Gate Module																																																												
R	2011	ALL	Body	Park Assist Module																																																												
R	2011	ALL	Body	Passenger Door Switch																																																												
R	2011	ALL	Body	Passenger Presence System																																																												
R	2011	ALL	Body	Radio																																																												
R	2011	ALL	Body	Rear HVAC/RSA																																																												
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2011	ALL	Body	Theft Deterrent Module																																																												
R	2012	ALL	Powertrain	Engine Control Module																																																												
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2012	ALL	Powertrain	Transmission Control Module																																																												
R	2012	ALL	Chassis	Electronic Brake Control Module																																																												
R	2012	ALL	Body	Body Control Module																																																												
R	2012	ALL	Body	Digital Radio Receiver																																																												
R	2012	ALL	Body	Driver Door Switch																																																												
R	2012	ALL	Body	Head Up Display																																																												
R	2012	ALL	Body	Heated Seat Module																																																												
R	2012	ALL	Body	HVAC Control Module Auto																																																												
R	2012	ALL	Body	HVAC Control Module Manual																																																												
R	2012	ALL	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2012	ALL	Body	Lift Gate Module																																																										
R	2012	ALL	Body	Park Assist Module																																																										
R	2012	ALL	Body	Passenger Door Switch																																																										
R	2012	ALL	Body	Passenger Presence System																																																										
R	2012	ALL	Body	Radio																																																										
R	2012	ALL	Body	Rear HVAC/RSA																																																										
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2012	ALL	Body	Theft Deterrent Module																																																										
R	2013	ALL	Powertrain	Engine Control Module																																																										
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2013	ALL	Powertrain	Transmission Control Module																																																										
R	2013	ALL	Chassis	Electronic Brake Control Module																																																										
R	2013	ALL	Body	Body Control Module																																																										
R	2013	ALL	Body	Digital Radio Receiver																																																										
R	2013	ALL	Body	Driver Door Switch																																																										
R	2013	ALL	Body	Head Up Display																																																										
R	2013	ALL	Body	Heated Seat Module																																																										
R	2013	ALL	Body	HVAC Control Module Auto																																																										
R	2013	ALL	Body	HVAC Control Module Manual																																																										
R	2013	ALL	Body	Instrument Panel Cluster																																																										
R	2013	ALL	Body	Left Side Object Detection Module																																																										
R	2013	ALL	Body	Lift Gate Module																																																										
R	2013	ALL	Body	Park Assist Module																																																										
R	2013	ALL	Body	Passenger Door Switch																																																										
R	2013	ALL	Body	Passenger Presence System																																																										
R	2013	ALL	Body	Radio																																																										
R	2013	ALL	Body	Rear HVAC/RSA																																																										
R	2013	ALL	Body	Right Side Object Detection Module																																																										
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2013	ALL	Body	Theft Deterrent Module																																																										
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2014	Acadia	Powertrain	Chassis Control Module																																																										
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
R	2014	Acadia	Chassis	Electronic Brake Control Module																																																										
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2014	Acadia	Body	Passenger Presence Module																																																										
R	2014	Acadia	Body	Instrument Cluster																																																										
R	2014	Acadia	Body	Head-Up Display Module																																																										
R	2014	Acadia	Body	Radio																																																										
R	2014	Acadia	Body	Rear Audio Control Module																																																										
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																										
R	2014	Acadia	Body	Personal Audio Link Control Module																																																										
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																											V																															
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																											V																															
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																										
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2014	Acadia	Body	Liftgate Control Module																																																											
R	2014	Acadia	Body	Seat Memory Control Module																																																												
R	2014	Acadia	Body	Front Seat Heating Control Module																																																												
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																												
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																												
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																												
R	2014	Acadia	Body	Parking Assist Control Module																																																												
R	2014	Acadia	Body	Frontview Camera Module																																																												
R	2014	Acadia	Body	Theft Deterrent Module																																																												
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
R	2015	Acadia	Chassis	Electronic Brake Control Module																																																												
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Acadia	Body	Passenger Presence Module																																																												
R	2015	Acadia	Body	Instrument Cluster																																																												
R	2015	Acadia	Body	Head-Up Display Module																																																												
R	2015	Acadia	Body	Radio																																																												
R	2015	Acadia	Body	Rear Audio Control Module																																																												
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																												
R	2015	Acadia	Body	Personal Audio Link Control Module																																																												
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																											V																																	
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																											V																																	
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																												
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																												
R	2015	Acadia	Body	Liftgate Control Module																																																												
R	2015	Acadia	Body	Seat Memory Control Module																																																												
R	2015	Acadia	Body	Front Seat Heating Control Module																																																												
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																												
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																												
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																												
R	2015	Acadia	Body	Parking Assist Control Module																																																												
R	2015	Acadia	Body	Frontview Camera Module																																																												
R	2015	Acadia	Body	Theft Deterrent Module																																																												
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
R	2016	Acadia	Chassis	Electronic Brake Control Module																																																												
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2016	Acadia	Body	Passenger Presence Module																																																												
R	2016	Acadia	Body	Instrument Cluster																																																												
R	2016	Acadia	Body	Head-Up Display Module																																																												
R	2016	Acadia	Body	Radio																																																											
R	2016	Acadia	Body	Rear Audio Control Module																																																												
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
R	2016	Acadia	Body	Personal Audio Link Control Module																																																											
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																												
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																											V																																	
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																											V																																	
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																											
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																											
R	2016	Acadia	Body	Liftgate Control Module																																																											
R	2016	Acadia	Body	Seat Memory Control Module																																																											
R	2016	Acadia	Body	Front Seat Heating Control Module																																																											
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																											
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																											
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																											
R	2016	Acadia	Body	Parking Assist Control Module																																																											
R	2016	Acadia	Body	Frontview Camera Module																																																											
R	2016	Acadia	Body	Theft Deterrent Module																																																											
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																											
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Sonoma	Body	Body Control Module																																																											
S	2004	Sonoma	Body	Instrument Panel Cluster																																																											
S	2004	Sonoma	Body	Base Radio																																																											
S	2004	Sonoma	Body	Uplevel Radio																																																											
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																											
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2004	Canyon	Chassis	ABS Without Traction Control																																																											
S	2004	Canyon	Chassis	ABS With Traction Control																																																											
S	2004	Canyon	Body	Body Control Module																																																											
S	2004	Canyon	Body	Instrument Panel Cluster																																																											
S	2004	Canyon	Body	OnStar																																																											
S	2004	Canyon	Body	Base Radio																																																											
S	2004	Canyon	Body	Uplevel Radio																																																											
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2004	Envoy	Chassis	ABS Without Traction Control																																																											
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Envoy	Body	Amplifier (Bose)																																																											
S	2004	Envoy	Body	Body Control Module																																																											
S	2004	Envoy	Body	Driver Door Module																																																											
S	2004	Envoy	Body	Driver Seat Module																																																											
S	2004	Envoy	Body	Heating and Air Conditioning Auto																																																											
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																											
S	2004	Envoy	Body	Instrument Panel Cluster																																																											
S	2004	Envoy	Body	Lift Gate Module																																																											
S	2004	Envoy	Body	OnStar																																																											
S	2004	Envoy	Body	Passenger Door Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2004	Envoy	Body	Uplevel Radio																																																											
S	2004	Envoy	Body	Navigation Radio																																																											
S	2004	Envoy	Body	Rear Seat Audio																																																											
S	2004	Envoy	Body	Rear Seat Entertainment																																																											
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																																											
S	2004	Envoy	Body	Vehicle Theft Deterrent																																																											
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																											
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																											
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																											
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Envoy XL	Body	Amplifier (Bose)																																																											
S	2004	Envoy XL	Body	Body Control Module																																																											
S	2004	Envoy XL	Body	Driver Door Module																																																											
S	2004	Envoy XL	Body	Driver Seat Module																																																											
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																											
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																											
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																											
S	2004	Envoy XL	Body	Lift Gate Module																																																											
S	2004	Envoy XL	Body	OnStar																																																											
S	2004	Envoy XL	Body	Passenger Door Module																																																											
S	2004	Envoy XL	Body	Uplevel Radio																																																											
S	2004	Envoy XL	Body	Navigation Radio																																																											
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																											
S	2004	Envoy XL	Body	Rear HVAC Manual																																																											
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																											
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																											
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																											
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																											
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																											
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																											
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																											
S	2004	Envoy XUV	Body	Body Control Module																																																											
S	2004	Envoy XUV	Body	Driver Door Module																																																											
S	2004	Envoy XUV	Body	Driver Seat Module																																																											
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																											
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																											
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																											
S	2004	Envoy XUV	Body	Lift Gate Module																																																											
S	2004	Envoy XUV	Body	OnStar																																																											
S	2004	Envoy XUV	Body	Passenger Door Module																																																											
S	2004	Envoy XUV	Body	Uplevel Radio																																																											
S	2004	Envoy XUV	Body	Navigation Radio																																																											
S	2004	Envoy XUV	Body	Rear Seat Audio																																																											
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																										
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Jimmy	Body	Body Control Module																																																										
S	2004	Jimmy	Body	Heating and Air Conditioning																																																										
S	2004	Jimmy	Body	Instrument Panel Cluster																																																										
S	2004	Jimmy	Body	Memory Seat Module																																																										
S	2004	Jimmy	Body	Base Radio																																																										
S	2004	Jimmy	Body	Uplevel Radio																																																										
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2005	Canyon	Chassis	ABS Without Traction Control																																																										
S	2005	Canyon	Chassis	ABS With Traction Control																																																										
S	2005	Canyon	Body	Body Control Module																																																										
S	2005	Canyon	Body	Instrument Panel Cluster																																																										
S	2005	Canyon	Body	Base Radio																																																										
S	2005	Canyon	Body	Uplevel Radio																																																										
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy	Body	Body Control Module																																																										
S	2005	Envoy	Body	Disc Player and Video Display																																																										
S	2005	Envoy	Body	Driver Door Module																																																										
S	2005	Envoy	Body	Driver Seat Module																																																										
S	2005	Envoy	Body	Heating and Air Conditioning Auto																																																										
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy	Body	Instrument Panel Cluster																																																										
S	2005	Envoy	Body	Lift Gate Module																																																										
S	2005	Envoy	Body	Passenger Door Module																																																										
S	2005	Envoy	Body	Passenger Presence System																																																										
S	2005	Envoy	Body	Uplevel Radio																																																										
S	2005	Envoy	Body	Navigation Radio																																																										
S	2005	Envoy	Body	Rear Seat Audio																																																										
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy XL	Body	Body Control Module																																																										
S	2005	Envoy XL	Body	Disc Player and Video Display																																																										
S	2005	Envoy XL	Body	Driver Door Module																																																										
S	2005	Envoy XL	Body	Driver Seat Module																																																										
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy XL	Body	Instrument Panel Cluster																																																										
S	2005	Envoy XL	Body	Lift Gate Module																																																										
S	2005	Envoy XL	Body	Passenger Door Module																																																										
S	2005	Envoy XL	Body	Passenger Presence System																																																										
S	2005	Envoy XL	Body	Uplevel Radio																																																										
S	2005	Envoy XL	Body	Navigation Radio																																																										
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
S	2005	Envoy XL	Body	Rear HVAC Manual																																																										
S	2005	Envoy XL	Body	Rear Seat Audio																																																										
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																										
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy XUV	Body	Body Control Module																																																										
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																										
S	2005	Envoy XUV	Body	Driver Door Module																																																										
S	2005	Envoy XUV	Body	Driver Seat Module																																																										
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																										
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																																										
S	2005	Envoy XUV	Body	Lift Gate Module																																																										
S	2005	Envoy XUV	Body	Passenger Door Module																																																										
S	2005	Envoy XUV	Body	Passenger Presence System																																																										
S	2005	Envoy XUV	Body	Uplevel Radio																																																										
S	2005	Envoy XUV	Body	Navigation Radio																																																										
S	2005	Envoy XUV	Body	Rear Seat Audio																																																										
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																										
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Jimmy	Body	Body Control Module																																																										
S	2005	Jimmy	Body	Heating and Air Conditioning																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2005	Jimmy	Body	Instrument Panel Cluster																																																											
S	2005	Jimmy	Body	Memory Seat Module																																																												
S	2005	Jimmy	Body	Base Radio																																																											
S	2005	Jimmy	Body	Uplevel Radio																																																											
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																											
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																											
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																											
S	2005	Sonoma	Body	Body Control Module																																																											
S	2005	Sonoma	Body	Instrument Panel Cluster																																																											
S	2005	Sonoma	Body	Base Radio																																																											
S	2005	Sonoma	Body	Uplevel Radio																																																											
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																											
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2006	Canyon	Chassis	ABS Without Traction Control																																																											
S	2006	Canyon	Chassis	ABS With Traction Control																																																											
S	2006	Canyon	Body	Body Control Module																																																											
S	2006	Canyon	Body	Instrument Panel Cluster																																																											
S	2006	Canyon	Body	Passenger Presence System																																																											
S	2006	Canyon	Body	Base Radio																																																											
S	2006	Canyon	Body	Uplevel Radio																																																											
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																																											
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2006	Envoy	Chassis	ABS/TCS/VSES																																																											
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																											
S	2006	Envoy	Body	Body Control Module																																																											
S	2006	Envoy	Body	Disc Player and Video Display																																																											
S	2006	Envoy	Body	Driver Door Module																																																											
S	2006	Envoy	Body	Driver Seat Module																																																											
S	2006	Envoy	Body	Heating and Air Conditioning Auto																																																											
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																																											
S	2006	Envoy	Body	Instrument Panel Cluster																																																											
S	2006	Envoy	Body	Lift Gate Module																																																											
S	2006	Envoy	Body	Passenger Door Module																																																											
S	2006	Envoy	Body	Passenger Presence System																																																											
S	2006	Envoy	Body	Uplevel Radio																																																											
S	2006	Envoy	Body	Navigation Radio																																																											
S	2006	Envoy	Body	Rear Seat Audio																																																											
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																																											
S	2006	Envoy	Body	Vehicle Theft Deterrent																																																											
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																										
S	2006	Envoy XL	Body	Body Control Module																																																										
S	2006	Envoy XL	Body	Disc Player and Video Display																																																										
S	2006	Envoy XL	Body	Driver Door Module																																																										
S	2006	Envoy XL	Body	Driver Seat Module																																																										
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
S	2006	Envoy XL	Body	Instrument Panel Cluster																																																										
S	2006	Envoy XL	Body	Lift Gate Module																																																										
S	2006	Envoy XL	Body	Passenger Door Module																																																										
S	2006	Envoy XL	Body	Passenger Presence System																																																										
S	2006	Envoy XL	Body	Uplevel Radio																																																										
S	2006	Envoy XL	Body	Navigation Radio																																																										
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
S	2006	Envoy XL	Body	Rear HVAC Manual																																																										
S	2006	Envoy XL	Body	Rear Seat Audio																																																										
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																										
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																										
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																										
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																										
S	2007	Canyon	Body	Body Control Module																																																										
S	2007	Canyon	Body	Digital Radio Receiver																																																										
S	2007	Canyon	Body	Generator Battery Control Module																																																										
S	2007	Canyon	Body	Instrument Panel Cluster																																																										
S	2007	Canyon	Body	Passenger Presence System																																																										
S	2007	Canyon	Body	Base Radio																																																										
S	2007	Canyon	Body	Uplevel Radio																																																										
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																										
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																										
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2007	Envoy	Chassis	Electronic Brake Control Module																																																										
S	2007	Envoy	Body	Body Control Module																																																										
S	2007	Envoy	Body	Digital Radio Receiver																																																										
S	2007	Envoy	Body	Disc Player and Video Display																																																										
S	2007	Envoy	Body	Driver Door Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2007	Envoy	Body	Driver Seat Module																																																										
S	2007	Envoy	Body	Generator Battery Control Module																																																										
S	2007	Envoy	Body	HVAC Control Module Auto																																																										
S	2007	Envoy	Body	HVAC Control Module Manual																																																										
S	2007	Envoy	Body	Instrument Panel Cluster																																																										
S	2007	Envoy	Body	Lift Gate Module																																																										
S	2007	Envoy	Body	Passenger Door Module																																																										
S	2007	Envoy	Body	Passenger Presence System																																																										
S	2007	Envoy	Body	Uplevel Radio																																																										
S	2007	Envoy	Body	Navigation Radio																																																										
S	2007	Envoy	Body	Rear Seat Audio																																																										
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2007	Envoy	Body	Theft Deterrent Module																																																										
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																																										
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																										
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																										
S	2008	Canyon	Body	Body Control Module																																																										
S	2008	Canyon	Body	Digital Radio Receiver																																																										
S	2008	Canyon	Body	Generator Battery Control Module																																																										
S	2008	Canyon	Body	Instrument Panel Cluster																																																										
S	2008	Canyon	Body	Passenger Presence System																																																										
S	2008	Canyon	Body	Base Radio																																																										
S	2008	Canyon	Body	Uplevel Radio																																																										
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2008	Canyon	Body	Theft Deterrent Module																																																										
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2008	Envoy	Chassis	Electronic Brake Control Module																																																										
S	2008	Envoy	Body	Body Control Module																																																										
S	2008	Envoy	Body	Digital Radio Receiver																																																										
S	2008	Envoy	Body	Disc Player and Video Display																																																										
S	2008	Envoy	Body	Driver Door Module																																																										
S	2008	Envoy	Body	Driver Seat Module																																																										
S	2008	Envoy	Body	Generator Battery Control Module																																																										
S	2008	Envoy	Body	HVAC Control Module Auto																																																										
S	2008	Envoy	Body	HVAC Control Module Manual																																																										
S	2008	Envoy	Body	Instrument Panel Cluster																																																										
S	2008	Envoy	Body	Lift Gate Module																																																										
S	2008	Envoy	Body	Passenger Door Module																																																										
S	2008	Envoy	Body	Passenger Presence System																																																										
S	2008	Envoy	Body	Uplevel Radio																																																										
S	2008	Envoy	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2008	Envoy	Body	Rear Seat Audio																																																											
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2008	Envoy	Body	Theft Deterrent Module																																																												
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																																												
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																												
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																												
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																												
S	2009	Canyon	Chassis	Electronic Brake Control Module																																																												
S	2009	Canyon	Body	Body Control Module																																																												
S	2009	Canyon	Body	Digital Radio Receiver																																																												
S	2009	Canyon	Body	Generator Battery Control Module																																																												
S	2009	Canyon	Body	Instrument Panel Cluster																																																												
S	2009	Canyon	Body	Passenger Presence System																																																												
S	2009	Canyon	Body	Base Radio																																																												
S	2009	Canyon	Body	Uplevel Radio																																																												
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																																												
S	2009	Canyon	Body	Theft Deterrent Module																																																												
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																												
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																												
S	2009	Envoy	Chassis	Electronic Brake Control Module																																																												
S	2009	Envoy	Body	Body Control Module																																																												
S	2009	Envoy	Body	Digital Radio Receiver																																																												
S	2009	Envoy	Body	Disc Player and Video Display																																																												
S	2009	Envoy	Body	Driver Door Module																																																												
S	2009	Envoy	Body	Driver Seat Module																																																												
S	2009	Envoy	Body	Generator Battery Control Module																																																												
S	2009	Envoy	Body	HVAC Control Module Auto																																																												
S	2009	Envoy	Body	HVAC Control Module Manual																																																												
S	2009	Envoy	Body	Instrument Panel Cluster																																																												
S	2009	Envoy	Body	Lift Gate Module																																																												
S	2009	Envoy	Body	Passenger Door Module																																																												
S	2009	Envoy	Body	Passenger Presence System																																																												
S	2009	Envoy	Body	Uplevel Radio																																																												
S	2009	Envoy	Body	Navigation Radio																																																												
S	2009	Envoy	Body	Rear Seat Audio																																																												
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2009	Envoy	Body	Theft Deterrent Module																																																												
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2010	ALL	Chassis	Electronic Brake Control Module																																																										
S	2010	ALL	Body	Body Control Module																																																										
S	2010	ALL	Body	Digital Radio Receiver																																																										
S	2010	ALL	Body	Generator Battery Control Module																																																										
S	2010	ALL	Body	Instument Panel Cluster																																																										
S	2010	ALL	Body	Passenger Presence System																																																										
S	2010	ALL	Body	Personal Audio Link Module																																																										
S	2010	ALL	Body	Base Radio																																																										
S	2010	ALL	Body	Uplevel Radio																																																										
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
S	2010	ALL	Body	Theft Deterrent Module																																																										
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																										
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																										
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Sonoma	Body	Body Control Module																																																										
T	2004	Sonoma	Body	Instrument Panel Cluster																																																										
T	2004	Sonoma	Body	Base Radio																																																										
T	2004	Sonoma	Body	Uplevel Radio																																																										
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																										
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2004	Canyon	Chassis	ABS Without Traction Control																																																										
T	2004	Canyon	Chassis	ABS With Traction Control																																																										
T	2004	Canyon	Body	Body Control Module																																																										
T	2004	Canyon	Body	Instrument Panel Cluster																																																										
T	2004	Canyon	Body	OnStar																																																										
T	2004	Canyon	Body	Base Radio																																																										
T	2004	Canyon	Body	Uplevel Radio																																																										
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2004	Canyon	Body	Instrument Panel Cluster																																																										
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2004	Envoy	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2004	Envoy	Body	Body Control Module																																																										
T	2004	Envoy	Body	Driver Door Module																																																										
T	2004	Envoy	Body	Driver Seat Module																																																										
T	2004	Envoy	Body	Heating and Air Conditioning Auto																																																										
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																																										
T	2004	Envoy	Body	Instrument Panel Cluster																																																										
T	2004	Envoy	Body	Lift Gate Module																																																										
T	2004	Envoy	Body	OnStar																																																										
T	2004	Envoy	Body	Passenger Door Module																																																										
T	2004	Envoy	Body	Uplevel Radio																																																										
T	2004	Envoy	Body	Navigation Radio																																																										
T	2004	Envoy	Body	Rear Seat Audio																																																										
T	2004	Envoy	Body	Rear Seat Entertainment																																																										
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy XL	Body	Amplifier (Bose)																																																										
T	2004	Envoy XL	Body	Body Control Module																																																										
T	2004	Envoy XL	Body	Driver Door Module																																																										
T	2004	Envoy XL	Body	Driver Seat Module																																																										
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2004	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2004	Envoy XL	Body	Lift Gate Module																																																										
T	2004	Envoy XL	Body	OnStar																																																										
T	2004	Envoy XL	Body	Passenger Door Module																																																										
T	2004	Envoy XL	Body	Uplevel Radio																																																										
T	2004	Envoy XL	Body	Navigation Radio																																																										
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2004	Envoy XL	Body	Rear HVAC Manual																																																										
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																										
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2004	Envoy XUV	Body	Body Control Module																																																											
T	2004	Envoy XUV	Body	Driver Door Module																																																												
T	2004	Envoy XUV	Body	Driver Seat Module																																																												
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																												
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																												
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																																												
T	2004	Envoy XUV	Body	Lift Gate Module																																																												
T	2004	Envoy XUV	Body	OnStar																																																												
T	2004	Envoy XUV	Body	Passenger Door Module																																																												
T	2004	Envoy XUV	Body	Uplevel Radio																																																												
T	2004	Envoy XUV	Body	Navigation Radio																																																												
T	2004	Envoy XUV	Body	Rear Seat Audio																																																												
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																												
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																												
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																												
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																												
T	2004	Jimmy	Body	Body Control Module																																																												
T	2004	Jimmy	Body	Heating and Air Conditioning																																																												
T	2004	Jimmy	Body	Instrument Panel Cluster																																																												
T	2004	Jimmy	Body	Memory Seat Module																																																												
T	2004	Jimmy	Body	Base Radio																																																												
T	2004	Jimmy	Body	Uplevel Radio																																																												
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																												
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2005	Canyon	Chassis	ABS Without Traction Control																																																												
T	2005	Canyon	Chassis	ABS With Traction Control																																																												
T	2005	Canyon	Body	Body Control Module																																																												
T	2005	Canyon	Body	Instrument Panel Cluster																																																												
T	2005	Canyon	Body	Base Radio																																																												
T	2005	Canyon	Body	Uplevel Radio																																																												
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																											
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																											
T	2005	Envoy	Chassis	ABS Without Traction Control																																																												
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Envoy	Body	Body Control Module																																																												
T	2005	Envoy	Body	Disc Player and Video Display																																																												
T	2005	Envoy	Body	Driver Door Module																																																												
T	2005	Envoy	Body	Driver Seat Module																																																												
T	2005	Envoy	Body	Heating and Air Conditioning Auto																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																																										
T	2005	Envoy	Body	Instrument Panel Cluster																																																										
T	2005	Envoy	Body	Lift Gate Module																																																										
T	2005	Envoy	Body	Passenger Door Module																																																										
T	2005	Envoy	Body	Passenger Presence System																																																										
T	2005	Envoy	Body	Uplevel Radio																																																										
T	2005	Envoy	Body	Navigation Radio																																																										
T	2005	Envoy	Body	Rear Seat Audio																																																										
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2005	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy XL	Body	Body Control Module																																																										
T	2005	Envoy XL	Body	Disc Player and Video Display																																																										
T	2005	Envoy XL	Body	Driver Door Module																																																										
T	2005	Envoy XL	Body	Driver Seat Module																																																										
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2005	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2005	Envoy XL	Body	Lift Gate Module																																																										
T	2005	Envoy XL	Body	Passenger Door Module																																																										
T	2005	Envoy XL	Body	Passenger Presence System																																																										
T	2005	Envoy XL	Body	Uplevel Radio																																																										
T	2005	Envoy XL	Body	Navigation Radio																																																										
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2005	Envoy XL	Body	Rear HVAC Manual																																																										
T	2005	Envoy XL	Body	Rear Seat Audio																																																										
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																										
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy XUV	Body	Body Control Module																																																										
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																										
T	2005	Envoy XUV	Body	Driver Door Module																																																										
T	2005	Envoy XUV	Body	Driver Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																											
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																												
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																																												
T	2005	Envoy XUV	Body	Lift Gate Module																																																												
T	2005	Envoy XUV	Body	Passenger Door Module																																																												
T	2005	Envoy XUV	Body	Passenger Presence System																																																												
T	2005	Envoy XUV	Body	Uplevel Radio																																																												
T	2005	Envoy XUV	Body	Navigation Radio																																																												
T	2005	Envoy XUV	Body	Rear Seat Audio																																																												
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																												
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																												
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																												
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																												
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Jimmy	Body	Body Control Module																																																												
T	2005	Jimmy	Body	Heating and Air Conditioning																																																												
T	2005	Jimmy	Body	Instrument Panel Cluster																																																												
T	2005	Jimmy	Body	Memory Seat Module																																																												
T	2005	Jimmy	Body	Base Radio																																																												
T	2005	Jimmy	Body	Uplevel Radio																																																												
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																												
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																												
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Sonoma	Body	Body Control Module																																																												
T	2005	Sonoma	Body	Instrument Panel Cluster																																																												
T	2005	Sonoma	Body	Base Radio																																																												
T	2005	Sonoma	Body	Uplevel Radio																																																												
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																												
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2006	Canyon	Chassis	ABS Without Traction Control																																																												
T	2006	Canyon	Chassis	ABS With Traction Control																																																												
T	2006	Canyon	Body	Body Control Module																																																												
T	2006	Canyon	Body	Instrument Panel Cluster																																																												
T	2006	Canyon	Body	Passenger Presence System																																																												
T	2006	Canyon	Body	Base Radio																																																												
T	2006	Canyon	Body	Uplevel Radio																																																												
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																																												
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2006	Envoy	Chassis	ABS/TCS/VSES																																																										
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																										
T	2006	Envoy	Body	Body Control Module																																																										
T	2006	Envoy	Body	Disc Player and Video Display																																																										
T	2006	Envoy	Body	Driver Door Module																																																										
T	2006	Envoy	Body	Driver Seat Module																																																										
T	2006	Envoy	Body	Heating and Air Conditioning Auto																																																										
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																																										
T	2006	Envoy	Body	Instrument Panel Cluster																																																										
T	2006	Envoy	Body	Lift Gate Module																																																										
T	2006	Envoy	Body	Passenger Door Module																																																										
T	2006	Envoy	Body	Passenger Presence System																																																										
T	2006	Envoy	Body	Uplevel Radio																																																										
T	2006	Envoy	Body	Navigation Radio																																																										
T	2006	Envoy	Body	Rear Seat Audio																																																										
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2006	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																										
T	2006	Envoy XL	Body	Body Control Module																																																										
T	2006	Envoy XL	Body	Disc Player and Video Display																																																										
T	2006	Envoy XL	Body	Driver Door Module																																																										
T	2006	Envoy XL	Body	Driver Seat Module																																																										
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2006	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2006	Envoy XL	Body	Lift Gate Module																																																										
T	2006	Envoy XL	Body	Passenger Door Module																																																										
T	2006	Envoy XL	Body	Passenger Presence System																																																										
T	2006	Envoy XL	Body	Uplevel Radio																																																										
T	2006	Envoy XL	Body	Navigation Radio																																																										
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2006	Envoy XL	Body	Rear HVAC Manual																																																										
T	2006	Envoy XL	Body	Rear Seat Audio																																																										
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																										
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																												
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																												
T	2007	Canyon	Body	Body Control Module																																																												
T	2007	Canyon	Body	Digital Radio Receiver																																																												
T	2007	Canyon	Body	Generator Battery Control Module																																																												
T	2007	Canyon	Body	Instrument Panel Cluster																																																												
T	2007	Canyon	Body	Passenger Presence System																																																												
T	2007	Canyon	Body	Base Radio																																																												
T	2007	Canyon	Body	Uplevel Radio																																																												
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																												
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																												
T	2007	Envoy	Chassis	Electronic Brake Control Module																																																												
T	2007	Envoy	Body	Body Control Module																																																												
T	2007	Envoy	Body	Digital Radio Receiver																																																												
T	2007	Envoy	Body	Disc Player and Video Display																																																												
T	2007	Envoy	Body	Driver Door Module																																																												
T	2007	Envoy	Body	Driver Seat Module																																																												
T	2007	Envoy	Body	Generator Battery Control Module																																																												
T	2007	Envoy	Body	HVAC Control Module Auto																																																												
T	2007	Envoy	Body	HVAC Control Module Manual																																																												
T	2007	Envoy	Body	Instrument Panel Cluster																																																												
T	2007	Envoy	Body	Lift Gate Module																																																												
T	2007	Envoy	Body	Passenger Door Module																																																												
T	2007	Envoy	Body	Passenger Presence System																																																												
T	2007	Envoy	Body	Uplevel Radio																																																												
T	2007	Envoy	Body	Navigation Radio																																																												
T	2007	Envoy	Body	Rear Seat Audio																																																												
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2007	Envoy	Body	Theft Deterrent Module																																																												
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																																												
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2008	Canyon	Body	Body Control Module																																																										
T	2008	Canyon	Body	Digital Radio Receiver																																																										
T	2008	Canyon	Body	Generator Battery Control Module																																																										
T	2008	Canyon	Body	Instrument Panel Cluster																																																										
T	2008	Canyon	Body	Passenger Presence System																																																										
T	2008	Canyon	Body	Base Radio																																																										
T	2008	Canyon	Body	Uplevel Radio																																																										
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2008	Canyon	Body	Theft Deterrent Module																																																										
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2008	Envoy	Chassis	Electronic Brake Control Module																																																										
T	2008	Envoy	Body	Body Control Module																																																										
T	2008	Envoy	Body	Digital Radio Receiver																																																										
T	2008	Envoy	Body	Disc Player and Video Display																																																										
T	2008	Envoy	Body	Driver Door Module																																																										
T	2008	Envoy	Body	Driver Seat Module																																																										
T	2008	Envoy	Body	Generator Battery Control Module																																																										
T	2008	Envoy	Body	HVAC Control Module Auto																																																										
T	2008	Envoy	Body	HVAC Control Module Manual																																																										
T	2008	Envoy	Body	Instrument Panel Cluster																																																										
T	2008	Envoy	Body	Lift Gate Module																																																										
T	2008	Envoy	Body	Passenger Door Module																																																										
T	2008	Envoy	Body	Passenger Presence System																																																										
T	2008	Envoy	Body	Uplevel Radio																																																										
T	2008	Envoy	Body	Navigation Radio																																																										
T	2008	Envoy	Body	Rear Seat Audio																																																										
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2008	Envoy	Body	Theft Deterrent Module																																																										
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																										
T	2009	Canyon	Chassis	Electronic Brake Control Module																																																										
T	2009	Canyon	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2009	Canyon	Body	Digital Radio Receiver																																																											
T	2009	Canyon	Body	Generator Battery Control Module																																																												
T	2009	Canyon	Body	Instrument Panel Cluster																																																												
T	2009	Canyon	Body	Passenger Presence System																																																												
T	2009	Canyon	Body	Base Radio																																																												
T	2009	Canyon	Body	Uplevel Radio																																																												
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2009	Canyon	Body	Theft Deterrent Module																																																												
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																													
T	2009	Envoy	Body	Body Control Module																																																												
T	2009	Envoy	Body	Digital Radio Receiver																																																												
T	2009	Envoy	Body	Disc Player and Video Display																																																												
T	2009	Envoy	Body	Driver Door Module																																																												
T	2009	Envoy	Body	Driver Seat Module																																																												
T	2009	Envoy	Body	Generator Battery Control Module																																																												
T	2009	Envoy	Body	HVAC Control Module Auto																																																												
T	2009	Envoy	Body	HVAC Control Module Manual																																																												
T	2009	Envoy	Body	Instrument Panel Cluster																																																												
T	2009	Envoy	Body	Lift Gate Module																																																												
T	2009	Envoy	Body	Passenger Door Module																																																												
T	2009	Envoy	Body	Passenger Presence System																																																												
T	2009	Envoy	Body	Uplevel Radio																																																												
T	2009	Envoy	Body	Navigation Radio																																																												
T	2009	Envoy	Body	Rear Seat Audio																																																												
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2009	Envoy	Body	Theft Deterrent Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																												
T	2010	ALL	Chassis	Electronic Brake Control Module																																																												
T	2010	ALL	Body	Body Control Module																																																												
T	2010	ALL	Body	Digital Radio Receiver																																																												
T	2010	ALL	Body	Generator Battery Control Module																																																												
T	2010	ALL	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
T	2010	ALL	Body	Passenger Presence System																																																											
T	2010	ALL	Body	Personal Audio Link Module																																																												
T	2010	ALL	Body	Base Radio																																																												
T	2010	ALL	Body	Uplevel Radio																																																												
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2010	ALL	Body	Theft Deterrent Module																																																												
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																												
V	2007	ALL	Powertrain	Engine Control Module																																																												
V	2007	ALL	Powertrain	Rear Drive System																																																												
V	2007	ALL	Powertrain	Transmission Control Module																																																												
V	2007	ALL	Chassis	Electronic Brake Control Module																																																												
V	2007	ALL	Body	Body Control Module																																																												
V	2007	ALL	Body	Digital Radio Receiver																																																												
V	2007	ALL	Body	Driver Door Switch																																																												
V	2007	ALL	Body	Head Up Display																																																												
V	2007	ALL	Body	Heated Seat Module																																																												
V	2007	ALL	Body	HVAC Control Module Auto																																																												
V	2007	ALL	Body	HVAC Control Module Manual																																																												
V	2007	ALL	Body	Instrument Panel Cluster																																																												
V	2007	ALL	Body	Lift Gate Module																																																												
V	2007	ALL	Body	Park Assist Module																																																												
V	2007	ALL	Body	Passenger Door Switch																																																												
V	2007	ALL	Body	Passenger Presence System																																																												
V	2007	ALL	Body	Radio																																																												
V	2007	ALL	Body	Rear HVAC/RSA																																																												
V	2007	ALL	Body	Rollover Sensor																																																												
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2007	ALL	Body	Theft Deterrent Module																																																												
V	2008	ALL	Powertrain	Engine Control Module																																																												
V	2008	ALL	Powertrain	Rear Drive System																																																												
V	2008	ALL	Powertrain	Transmission Control Module																																																												
V	2008	ALL	Chassis	Electronic Brake Control Module																																																												
V	2008	ALL	Body	Body Control Module																																																											
V	2008	ALL	Body	Digital Radio Receiver																																																												
V	2008	ALL	Body	Driver Door Switch																																																												
V	2008	ALL	Body	Head Up Display																																																												
V	2008	ALL	Body	Heated Seat Module																																																												
V	2008	ALL	Body	HVAC Control Module Auto																																																												
V	2008	ALL	Body	HVAC Control Module Manual																																																												
V	2008	ALL	Body	Instrument Panel Cluster																																																												
V	2008	ALL	Body	Lift Gate Module																																																												
V	2008	ALL	Body	Park Assist Module																																																												
V	2008	ALL	Body	Passenger Door Switch																																																												
V	2008	ALL	Body	Passenger Presence System																																																												
V	2008	ALL	Body	Radio																																																												
V	2008	ALL	Body	Rear HVAC/RSA																																																												
V	2008	ALL	Body	Rollover Sensor																																																												
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2008	ALL	Body	Theft Deterrent Module																																																												
V	2009	ALL	Powertrain	Engine Control Module																																																												
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
V	2009	ALL	Powertrain	Rear Drive System																																																											
V	2009	ALL	Powertrain	Transmission Control Module																																																												
V	2009	ALL	Chassis	Electronic Brake Control Module																																																												
V	2009	ALL	Body	Body Control Module																																																												
V	2009	ALL	Body	Digital Radio Receiver																																																												
V	2009	ALL	Body	Driver Door Switch																																																												
V	2009	ALL	Body	Head Up Display																																																												
V	2009	ALL	Body	Heated Seat Module																																																												
V	2009	ALL	Body	HVAC Control Module Auto																																																												
V	2009	ALL	Body	HVAC Control Module Manual																																																												
V	2009	ALL	Body	Instrument Panel Cluster																																																												
V	2009	ALL	Body	Lift Gate Module																																																												
V	2009	ALL	Body	Park Assist Module																																																												
V	2009	ALL	Body	Passenger Door Switch																																																												
V	2009	ALL	Body	Passenger Presence System																																																												
V	2009	ALL	Body	Radio																																																												
V	2009	ALL	Body	Rear HVAC/RSA																																																												
V	2009	ALL	Body	Rollover Sensor																																																												
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2009	ALL	Body	Theft Deterrent Module																																																												
V	2010	ALL	Powertrain	Engine Control Module																																																												
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2010	ALL	Powertrain	Rear Drive System																																																												
V	2010	ALL	Powertrain	Transmission Control Module																																																												
V	2010	ALL	Chassis	Electronic Brake Control Module																																																												
V	2010	ALL	Body	Body Control Module																																																												
V	2010	ALL	Body	Digital Radio Receiver																																																												
V	2010	ALL	Body	Driver Door Switch																																																												
V	2010	ALL	Body	Head Up Display																																																												
V	2010	ALL	Body	Heated Seat Module																																																												
V	2010	ALL	Body	HVAC Control Module Auto																																																												
V	2010	ALL	Body	HVAC Control Module Manual																																																												
V	2010	ALL	Body	Instrument Panel Cluster																																																												
V	2010	ALL	Body	Lift Gate Module																																																												
V	2010	ALL	Body	Park Assist Module																																																												
V	2010	ALL	Body	Passenger Door Switch																																																												
V	2010	ALL	Body	Passenger Presence System																																																												
V	2010	ALL	Body	Radio																																																												
V	2010	ALL	Body	Rear HVAC/RSA																																																												
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2010	ALL	Body	Theft Deterrent Module																																																												
V	2011	ALL	Powertrain	Engine Control Module																																																												
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2011	ALL	Powertrain	Rear Drive System																																																												
V	2011	ALL	Powertrain	Transmission Control Module																																																												
V	2011	ALL	Chassis	Electronic Brake Control Module																																																												
V	2011	ALL	Body	Body Control Module																																																												
V	2011	ALL	Body	Digital Radio Receiver																																																												
V	2011	ALL	Body	Driver Door Switch																																																												
V	2011	ALL	Body	Head Up Display																																																												
V	2011	ALL	Body	Heated Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
V	2011	ALL	Body	HVAC Control Module Auto																																																												
V	2011	ALL	Body	HVAC Control Module Manual																																																													
V	2011	ALL	Body	Instrument Panel Cluster																																																													
V	2011	ALL	Body	Lift Gate Module																																																													
V	2011	ALL	Body	Park Assist Module																																																													
V	2011	ALL	Body	Passenger Door Switch																																																													
V	2011	ALL	Body	Passenger Presence System																																																													
V	2011	ALL	Body	Radio																																																													
V	2011	ALL	Body	Rear HVAC/RSA																																																													
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																													
V	2011	ALL	Body	Theft Deterrent Module																																																													
V	2012	ALL	Powertrain	Engine Control Module																																																													
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																													
V	2012	ALL	Powertrain	Rear Drive System																																																													
V	2012	ALL	Powertrain	Transmission Control Module																																																													
V	2012	ALL	Chassis	Electronic Brake Control Module																																																													
V	2012	ALL	Body	Body Control Module																																																													
V	2012	ALL	Body	Digital Radio Receiver																																																													
V	2012	ALL	Body	Driver Door Switch																																																													
V	2012	ALL	Body	Head Up Display																																																													
V	2012	ALL	Body	Heated Seat Module																																																													
V	2012	ALL	Body	HVAC Control Module Auto																																																													
V	2012	ALL	Body	HVAC Control Module Manual																																																													
V	2012	ALL	Body	Instrument Panel Cluster																																																													
V	2012	ALL	Body	Lift Gate Module																																																													
V	2012	ALL	Body	Park Assist Module																																																													
V	2012	ALL	Body	Passenger Door Switch																																																													
V	2012	ALL	Body	Passenger Presence System																																																													
V	2012	ALL	Body	Radio																																																													
V	2012	ALL	Body	Rear HVAC/RSA																																																													
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																													
V	2012	ALL	Body	Theft Deterrent Module																																																													
V	2013	ALL	Powertrain	Engine Control Module																																																													
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																													
V	2013	ALL	Powertrain	Rear Drive System																																																													
V	2013	ALL	Powertrain	Transmission Control Module																																																													
V	2013	ALL	Chassis	Electronic Brake Control Module																																																													
V	2013	ALL	Body	Body Control Module																																																													
V	2013	ALL	Body	Digital Radio Receiver																																																													
V	2013	ALL	Body	Driver Door Switch																																																													
V	2013	ALL	Body	Head Up Display																																																													
V	2013	ALL	Body	Heated Seat Module																																																													
V	2013	ALL	Body	HVAC Control Module Auto																																																													
V	2013	ALL	Body	HVAC Control Module Manual																																																													
V	2013	ALL	Body	Instrument Panel Cluster																																																													
V	2013	ALL	Body	Left Side Object Detection Module																																																													
V	2013	ALL	Body	Lift Gate Module																																																													
V	2013	ALL	Body	Park Assist Module																																																													
V	2013	ALL	Body	Passenger Door Switch																																																													
V	2013	ALL	Body	Passenger Presence System																																																													
V	2013	ALL	Body	Radio																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
V	2013	ALL	Body	Rear HVAC/RSA																																																											
V	2013	ALL	Body	Right Side Object Detection Module																																																												
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2013	ALL	Body	Theft Deterrent Module																																																												
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2014	Acadia	Powertrain	Chassis Control Module																																																												
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
V	2014	Acadia	Chassis	Electronic Brake Control Module																																																												
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2014	Acadia	Body	Passenger Presence Module																																																												
V	2014	Acadia	Body	Instrument Cluster																																																												
V	2014	Acadia	Body	Head-Up Display Module																																																												
V	2014	Acadia	Body	Radio																																																												
V	2014	Acadia	Body	Rear Audio Control Module																																																												
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																												
V	2014	Acadia	Body	Personal Audio Link Control Module																																																												
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																											V																																	
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																											V																																	
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																												
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																												
V	2014	Acadia	Body	Liftgate Control Module																																																												
V	2014	Acadia	Body	Seat Memory Control Module																																																												
V	2014	Acadia	Body	Front Seat Heating Control Module																																																												
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																												
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																												
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																												
V	2014	Acadia	Body	Parking Assist Control Module																																																												
V	2014	Acadia	Body	Frontview Camera Module																																																												
V	2014	Acadia	Body	Theft Deterrent Module																																																												
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
V	2015	Acadia	Chassis	Electronic Brake Control Module																																																												
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2015	Acadia	Body	Passenger Presence Module																																																												
V	2015	Acadia	Body	Instrument Cluster																																																												
V	2015	Acadia	Body	Head-Up Display Module																																																												
V	2015	Acadia	Body	Radio																																																												
V	2015	Acadia	Body	Rear Audio Control Module																																																												
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																												
V	2015	Acadia	Body	Personal Audio Link Control Module																																																												
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																											V																																	

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																											V																																
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																											
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																											
V	2015	Acadia	Body	Liftgate Control Module																																																											
V	2015	Acadia	Body	Seat Memory Control Module																																																											
V	2015	Acadia	Body	Front Seat Heating Control Module																																																											
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																											
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																											
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																											
V	2015	Acadia	Body	Parking Assist Control Module																																																											
V	2015	Acadia	Body	Frontview Camera Module																																																												
V	2015	Acadia	Body	Theft Deterrent Module																																																												
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
V	2016	Acadia	Chassis	Electronic Brake Control Module																																																												
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2016	Acadia	Body	Passenger Presence Module																																																												
V	2016	Acadia	Body	Instrument Cluster																																																												
V	2016	Acadia	Body	Head-Up Display Module																																																												
V	2016	Acadia	Body	Radio																																																											
V	2016	Acadia	Body	Rear Audio Control Module																																																												
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																												
V	2016	Acadia	Body	Personal Audio Link Control Module																																																												
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																												
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																											V																																	
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																											V																																	
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																											
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																											
V	2016	Acadia	Body	Liftgate Control Module																																																											
V	2016	Acadia	Body	Seat Memory Control Module																																																											
V	2016	Acadia	Body	Front Seat Heating Control Module																																																											
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																											
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																											
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																											
V	2016	Acadia	Body	Parking Assist Control Module																																																											
V	2016	Acadia	Body	Frontview Camera Module																																																											
V	2016	Acadia	Body	Theft Deterrent Module																																																											
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
1	2011	Sierra	Chassis	Electronic Suspension Control																																																												
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																												
1	2011	Sierra	Body	Amplifier (Bose)																																																												
1	2011	Sierra	Body	Body Control Module																																																												
1	2011	Sierra	Body	Body Control Module (aux.)																																																												
1	2011	Sierra	Body	Digital Radio Receiver																																																												
1	2011	Sierra	Body	Driver Door Switch																																																												
1	2011	Sierra	Body	HVAC Control Module Auto																																																												
1	2011	Sierra	Body	HVAC Control Module Manual																																																												
1	2011	Sierra	Body	Instrument Panel Cluster																																																												
1	2011	Sierra	Body	Memory Seat Module																																																												
1	2011	Sierra	Body	Park Assist Module																																																												
1	2011	Sierra	Body	Passenger Door Switch																																																												
1	2011	Sierra	Body	Passenger Presence System																																																												
1	2011	Sierra	Body	Radio																																																											
1	2011	Sierra	Body	Rear Heated Seat Module																																																												
1	2011	Sierra	Body	Rear HVAC/RSA																																																												
1	2011	Sierra	Body	Supplemental Inflatable Restraint																																																												
1	2011	Sierra	Body	Theft Deterrent Module																																																												
1	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																												
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																												
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																												
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																												
1	2011	Sierra Hybrid	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2011	Sierra Hybrid	Body	Driver Door Switch																																																										
1	2011	Sierra Hybrid	Body	Heated Seat Module																																																										
1	2011	Sierra Hybrid	Body	HVAC Control Module																																																										
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2011	Sierra Hybrid	Body	Park Assist Module																																																										
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																																										
1	2011	Sierra Hybrid	Body	Passenger Presence System																																																										
1	2011	Sierra Hybrid	Body	Radio																																																										
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2011	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2011	Yukon	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																										
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon	Body	Amplifier (Bose)																																																										
1	2011	Yukon	Body	Assist Step Controller																																																										
1	2011	Yukon	Body	Body Control Module																																																										
1	2011	Yukon	Body	Body Control Module (aux.)																																																										
1	2011	Yukon	Body	Digital Radio Receiver																																																										
1	2011	Yukon	Body	Driver Door Switch																																																										
1	2011	Yukon	Body	HVAC Control Module Auto																																																										
1	2011	Yukon	Body	HVAC Control Module Manual																																																										
1	2011	Yukon	Body	Instrument Panel Cluster																																																										
1	2011	Yukon	Body	Left Side Object Detection Module																																																										
1	2011	Yukon	Body	Lift Gate Module																																																										
1	2011	Yukon	Body	Memory Seat Module																																																										
1	2011	Yukon	Body	Park Assist Module																																																										
1	2011	Yukon	Body	Passenger Door Switch																																																										
1	2011	Yukon	Body	Passenger Presence System																																																										
1	2011	Yukon	Body	Radio																																																										
1	2011	Yukon	Body	Rear Heated Seat Module																																																										
1	2011	Yukon	Body	Rear HVAC/RSA																																																										
1	2011	Yukon	Body	Right Side Object Detection Module																																																										
1	2011	Yukon	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon	Body	Theft Deterrent Module																																																										
1	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2011	Yukon Hybrid	Body	Body Control Module																																																										
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																										
1	2011	Yukon Hybrid	Body	HVAC Control Module																																																										
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
1	2011	Yukon Hybrid	Body	Lift Gate Module																																																										
1	2011	Yukon Hybrid	Body	Park Assist Module																																																										
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2011	Yukon Hybrid	Body	Passenger Presence System																																																										
1	2011	Yukon Hybrid	Body	Radio																																																										
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																										
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon XL	Body	Amplifier (Bose)																																																										
1	2011	Yukon XL	Body	Assist Step Controller																																																										
1	2011	Yukon XL	Body	Body Control Module																																																										
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2011	Yukon XL	Body	Digital Radio Receiver																																																										
1	2011	Yukon XL	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2011	Yukon XL	Body	HVAC Control Module Auto																																																												
1	2011	Yukon XL	Body	HVAC Control Module Manual																																																												
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																												
1	2011	Yukon XL	Body	Left Side Object Detection Module																																																												
1	2011	Yukon XL	Body	Lift Gate Module																																																												
1	2011	Yukon XL	Body	Memory Seat Module																																																												
1	2011	Yukon XL	Body	Park Assist Module																																																												
1	2011	Yukon XL	Body	Passenger Door Switch																																																												
1	2011	Yukon XL	Body	Passenger Presence System																																																												
1	2011	Yukon XL	Body	Radio																																																												
1	2011	Yukon XL	Body	Rear Heated Seat Module																																																												
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																												
1	2011	Yukon XL	Body	Right Side Object Detection Module																																																												
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
1	2011	Yukon XL	Body	Theft Deterrent Module																																																												
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
1	2012	Sierra	Chassis	Electronic Suspension Control																																																												
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																												
1	2012	Sierra	Body	Amplifier (Bose)																																																												
1	2012	Sierra	Body	Body Control Module																																																												
1	2012	Sierra	Body	Body Control Module (aux.)																																																												
1	2012	Sierra	Body	Digital Radio Receiver																																																												
1	2012	Sierra	Body	Driver Door Switch																																																												
1	2012	Sierra	Body	HVAC Control Module Auto																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2012	Sierra	Body	HVAC Control Module Manual																																																										
1	2012	Sierra	Body	Instrument Panel Cluster																																																										
1	2012	Sierra	Body	Memory Seat Module																																																										
1	2012	Sierra	Body	Park Assist Module																																																										
1	2012	Sierra	Body	Passenger Door Switch																																																										
1	2012	Sierra	Body	Passenger Presence System																																																										
1	2012	Sierra	Body	Radio																																																										
1	2012	Sierra	Body	Navigation Radio																																																										
1	2012	Sierra	Body	Rear Heated Seat Module																																																										
1	2012	Sierra	Body	Rear HVAC/RSA																																																										
1	2012	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2012	Sierra	Body	Theft Deterrent Module																																																										
1	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
1	2012	Sierra Hybrid	Body	Body Control Module																																																										
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2012	Sierra Hybrid	Body	Driver Door Switch																																																										
1	2012	Sierra Hybrid	Body	Heated Seat Module																																																										
1	2012	Sierra Hybrid	Body	HVAC Control Module																																																										
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2012	Sierra Hybrid	Body	Park Assist Module																																																										
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																																										
1	2012	Sierra Hybrid	Body	Passenger Presence System																																																										
1	2012	Sierra Hybrid	Body	Radio																																																										
1	2012	Sierra Hybrid	Body	Navigation Radio																																																										
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2012	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2012	Yukon	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																											
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon	Body	Amplifier (Bose)																																																											
1	2012	Yukon	Body	Assist Step Controller																																																											
1	2012	Yukon	Body	Body Control Module																																																											
1	2012	Yukon	Body	Body Control Module (aux.)																																																											
1	2012	Yukon	Body	Digital Radio Receiver																																																											
1	2012	Yukon	Body	Driver Door Switch																																																											
1	2012	Yukon	Body	HVAC Control Module Auto																																																											
1	2012	Yukon	Body	HVAC Control Module Manual																																																											
1	2012	Yukon	Body	Instrument Panel Cluster																																																											
1	2012	Yukon	Body	Left Side Object Detection Module																																																											
1	2012	Yukon	Body	Lift Gate Module																																																											
1	2012	Yukon	Body	Memory Seat Module																																																											
1	2012	Yukon	Body	Park Assist Module																																																											
1	2012	Yukon	Body	Passenger Door Switch																																																											
1	2012	Yukon	Body	Passenger Presence System																																																											
1	2012	Yukon	Body	Radio																																																											
1	2012	Yukon	Body	Navigation Radio																																																											
1	2012	Yukon	Body	Rear Heated Seat Module																																																											
1	2012	Yukon	Body	Rear HVAC/RSA																																																											
1	2012	Yukon	Body	Right Side Object Detection Module																																																											
1	2012	Yukon	Body	Supplemental Inflatable Restraint																																																											
1	2012	Yukon	Body	Theft Deterrent Module																																																											
1	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																											
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																											
1	2012	Yukon Hybrid	Body	Body Control Module																																																											
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																											
1	2012	Yukon Hybrid	Body	Driver Door Switch																																																											
1	2012	Yukon Hybrid	Body	Heated Seat Module																																																											
1	2012	Yukon Hybrid	Body	HVAC Control Module																																																											
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
1	2012	Yukon Hybrid	Body	Lift Gate Module																																																											
1	2012	Yukon Hybrid	Body	Park Assist Module																																																											
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																																											
1	2012	Yukon Hybrid	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2012	Yukon Hybrid	Body	Radio																																																										
1	2012	Yukon Hybrid	Body	Navigation Radio																																																										
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																										
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																										
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Yukon XL	Body	Amplifier (Bose)																																																										
1	2012	Yukon XL	Body	Assist Step Controller																																																										
1	2012	Yukon XL	Body	Body Control Module																																																										
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2012	Yukon XL	Body	Digital Radio Receiver																																																										
1	2012	Yukon XL	Body	Driver Door Switch																																																										
1	2012	Yukon XL	Body	HVAC Control Module Auto																																																										
1	2012	Yukon XL	Body	HVAC Control Module Manual																																																										
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																										
1	2012	Yukon XL	Body	Left Side Object Detection Module																																																										
1	2012	Yukon XL	Body	Lift Gate Module																																																										
1	2012	Yukon XL	Body	Memory Seat Module																																																										
1	2012	Yukon XL	Body	Park Assist Module																																																										
1	2012	Yukon XL	Body	Passenger Door Switch																																																										
1	2012	Yukon XL	Body	Passenger Presence System																																																										
1	2012	Yukon XL	Body	Radio																																																										
1	2012	Yukon XL	Body	Navigation Radio																																																										
1	2012	Yukon XL	Body	Rear Heated Seat Module																																																										
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																										
1	2012	Yukon XL	Body	Right Side Object Detection Module																																																										
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
1	2012	Yukon XL	Body	Theft Deterrent Module																																																										
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																										
1	2013	Sierra	Chassis	Electronic Suspension Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Body	Amplifier (Bose)																																																										
1	2013	Sierra	Body	Body Control Module																																																										
1	2013	Sierra	Body	Body Control Module (aux.)																																																										
1	2013	Sierra	Body	Digital Radio Receiver																																																										
1	2013	Sierra	Body	Driver Door Switch																																																										
1	2013	Sierra	Body	HVAC Control Module Auto																																																										
1	2013	Sierra	Body	HVAC Control Module Manual																																																										
1	2013	Sierra	Body	Instrument Panel Cluster																																																										
1	2013	Sierra	Body	Memory Seat Module																																																										
1	2013	Sierra	Body	Park Assist Module																																																										
1	2013	Sierra	Body	Passenger Door Switch																																																										
1	2013	Sierra	Body	Passenger Presence System																																																										
1	2013	Sierra	Body	Radio																																																										
1	2013	Sierra	Body	Navigation Radio																																																										
1	2013	Sierra	Body	Rear Heated Seat Module																																																										
1	2013	Sierra	Body	Rear HVAC/RSA																																																										
1	2013	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2013	Sierra	Body	Theft Deterrent Module																																																										
1	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																												
1	2013	Sierra Hybrid	Body	Body Control Module																																																												
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																												
1	2013	Sierra Hybrid	Body	Driver Door Switch																																																												
1	2013	Sierra Hybrid	Body	Heated Seat Module																																																												
1	2013	Sierra Hybrid	Body	HVAC Control Module																																																												
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
1	2013	Sierra Hybrid	Body	Park Assist Module																																																												
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																																												
1	2013	Sierra Hybrid	Body	Passenger Presence System																																																												
1	2013	Sierra Hybrid	Body	Radio																																																												
1	2013	Sierra Hybrid	Body	Navigation Radio																																																												
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																												
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
1	2013	Yukon	Chassis	Electronic Brake Control Module																																																												
1	2013	Yukon	Chassis	Electronic Suspension Control																																																												
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon	Body	Amplifier (Bose)																																																												
1	2013	Yukon	Body	Assist Step Controller																																																												
1	2013	Yukon	Body	Body Control Module																																																												
1	2013	Yukon	Body	Body Control Module (aux.)																																																												
1	2013	Yukon	Body	Digital Radio Receiver																																																												
1	2013	Yukon	Body	Driver Door Switch																																																												
1	2013	Yukon	Body	HVAC Control Module Auto																																																												
1	2013	Yukon	Body	HVAC Control Module Manual																																																												
1	2013	Yukon	Body	Instrument Panel Cluster																																																												
1	2013	Yukon	Body	Left Side Object Detection Module																																																												
1	2013	Yukon	Body	Lift Gate Module																																																												
1	2013	Yukon	Body	Memory Seat Module																																																												
1	2013	Yukon	Body	Park Assist Module																																																												
1	2013	Yukon	Body	Passenger Door Switch																																																												
1	2013	Yukon	Body	Passenger Presence System																																																												
1	2013	Yukon	Body	Radio																																																												
1	2013	Yukon	Body	Navigation Radio																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2013	Yukon	Body	Rear Heated Seat Module																																																											
1	2013	Yukon	Body	Rear HVAC/RSA																																																											
1	2013	Yukon	Body	Right Side Object Detection Module																																																											
1	2013	Yukon	Body	Supplemental Inflatable Restraint																																																											
1	2013	Yukon	Body	Theft Deterrent Module																																																											
1	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																											
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																											
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																											
1	2013	Yukon Hybrid	Body	Body Control Module																																																											
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																											
1	2013	Yukon Hybrid	Body	Driver Door Switch																																																											
1	2013	Yukon Hybrid	Body	Heated Seat Module																																																											
1	2013	Yukon Hybrid	Body	HVAC Control Module																																																											
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
1	2013	Yukon Hybrid	Body	Lift Gate Module																																																											
1	2013	Yukon Hybrid	Body	Park Assist Module																																																											
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																																											
1	2013	Yukon Hybrid	Body	Passenger Presence System																																																											
1	2013	Yukon Hybrid	Body	Radio																																																											
1	2013	Yukon Hybrid	Body	Navigation Radio																																																											
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																											
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																											
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon XL	Body	Amplifier (Bose)																																																										
1	2013	Yukon XL	Body	Assist Step Controller																																																										
1	2013	Yukon XL	Body	Body Control Module																																																										
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2013	Yukon XL	Body	Digital Radio Receiver																																																										
1	2013	Yukon XL	Body	Driver Door Switch																																																										
1	2013	Yukon XL	Body	HVAC Control Module Auto																																																										
1	2013	Yukon XL	Body	HVAC Control Module Manual																																																										
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																										
1	2013	Yukon XL	Body	Left Side Object Detection Module																																																										
1	2013	Yukon XL	Body	Lift Gate Module																																																										
1	2013	Yukon XL	Body	Memory Seat Module																																																										
1	2013	Yukon XL	Body	Park Assist Module																																																										
1	2013	Yukon XL	Body	Passenger Door Switch																																																										
1	2013	Yukon XL	Body	Passenger Presence System																																																										
1	2013	Yukon XL	Body	Radio																																																										
1	2013	Yukon XL	Body	Navigation Radio																																																										
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																										
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																										
1	2013	Yukon XL	Body	Right Side Object Detection Module																																																										
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
1	2013	Yukon XL	Body	Theft Deterrent Module																																																										
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2014	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2014	Sierra	Chassis	Parking Brake Control Module																																																										
1	2014	Sierra	Chassis	Power Steering Control Module																																																										
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2014	Sierra	Body	Body Control Module																																																										
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Sierra	Body	Passenger Presence Module																																																										
1	2014	Sierra	Body	Instrument Cluster																																																										
1	2014	Sierra	Body	Radio Control																																																										
1	2014	Sierra	Body	HVAC Control																																																										
1	2014	Sierra	Body	Radio																																																										
1	2014	Sierra	Body	Amplifier																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2014	Sierra	Body	Media Disc Player																																																										
1	2014	Sierra	Body	Human Machine Interface Control Module																																																										
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2014	Sierra	Body	Parking Assist Control Module																																																										
1	2014	Sierra	Body	Frontview Camera Module																																																										
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																										
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Suspension Control Module																																																										
1	2014	Sierra HD	Body	Body Control Module																																																										
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Sierra HD	Body	Instrument Cluster																																																										
1	2014	Sierra HD	Body	Base Radio																																																										
1	2014	Sierra HD	Body	Navigation Radio																																																										
1	2014	Sierra HD	Body	Uplevel Radio																																																										
1	2014	Sierra HD	Body	Amplifier																																																										
1	2014	Sierra HD	Body	Rear Audio Control Module																																																										
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																										
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																										
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																											V																															
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																											V																															
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																											V																															
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Sierra HD	Body	Seat Memory Control Module																																																										
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																										
1	2014	Sierra HD	Body	Parking Assist Control Module																				V																																						
1	2014	Sierra HD	Body	Theft Deterrent Module																																																										
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																										
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2014	Yukon	Chassis	Electronic Brake Control Module																																																													
1	2014	Yukon	Chassis	Parking Brake Control Module																																																												
1	2014	Yukon	Chassis	Suspension Control Module																																																												
1	2014	Yukon	Body	Body Control Module																																																												
1	2014	Yukon	Body	Auxiliary Body Control Module																																																												
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	Yukon	Body	Passenger Presence Module																																																												
1	2014	Yukon	Body	Instrument Cluster																																																												
1	2014	Yukon	Body	Base Radio																																																												
1	2014	Yukon	Body	Navigation Radio																																																												
1	2014	Yukon	Body	Uplevel Radio																																																												
1	2014	Yukon	Body	Amplifier																																																												
1	2014	Yukon	Body	Rear Audio Control Module																																																												
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																																												
1	2014	Yukon	Body	Personal Audio Link Control Module																																																												
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																											V																																	
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																											V																																	
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																											
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																											
1	2014	Yukon	Body	Liftgate Control Module																																																											
1	2014	Yukon	Body	Seat Memory Control Module																																																											
1	2014	Yukon	Body	Rear Seat Heating Control Module																																																											
1	2014	Yukon	Body	Assist Step Control Module																																																											
1	2014	Yukon	Body	Right Side Object Detection Control Module																																																											
1	2014	Yukon	Body	Left Side Object Detection Control Module																																																											
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																																											
1	2014	Yukon	Body	Parking Assist Control Module																				V																																							
1	2014	Yukon	Body	Theft Deterrent Module																																																											
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																											
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																											
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																											
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																											
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																											
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																											
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																											
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																																											
1	2014	Yukon XL	Chassis	Suspension Control Module																																																											
1	2014	Yukon XL	Body	Body Control Module																																																											
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																																											
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	Yukon XL	Body	Passenger Presence Module																																																											
1	2014	Yukon XL	Body	Instrument Cluster																																																											
1	2014	Yukon XL	Body	Base Radio																																																											
1	2014	Yukon XL	Body	Navigation Radio																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2014	Yukon XL	Body	Uplevel Radio																																																										
1	2014	Yukon XL	Body	Amplifier																																																										
1	2014	Yukon XL	Body	Rear Audio Control Module																																																										
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																										
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																																										
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																											V																															
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																											V																															
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Yukon XL	Body	Liftgate Control Module																																																										
1	2014	Yukon XL	Body	Seat Memory Control Module																																																										
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																										
1	2014	Yukon XL	Body	Assist Step Control Module																																																										
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																										
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																										
1	2014	Yukon XL	Body	Parking Assist Control Module																				V																																						
1	2014	Yukon XL	Body	Theft Deterrent Module																																																										
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Sierra	Chassis	Power Steering Control Module																																																										
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Sierra	Chassis	Suspension Control Module																																																										
1	2015	Sierra	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	Sierra	Body	Passenger Presence Module																																																												
1	2015	Sierra	Body	Instrument Cluster																																																												
1	2015	Sierra	Body	Radio Controls																																																												
1	2015	Sierra	Body	HVAC Controls																																																												
1	2015	Sierra	Body	Radio																																																												
1	2015	Sierra	Body	Amplifier																																																												
1	2015	Sierra	Body	Media Disc Player																																																												
1	2015	Sierra	Body	Human Machine Interface Control Module																																																												
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																												
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																												
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
1	2015	Sierra	Body	Parking Assist Control Module																																																												
1	2015	Sierra	Body	Frontview Camera Module																																																												
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																												
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																												
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																												
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																												
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																												
1	2015	Yukon	Chassis	Electronic Brake Control Module																																																												
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																												
1	2015	Yukon	Chassis	Parking Brake Control Module																																																												
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2015	Yukon	Chassis	Power Steering Control Module																																																												
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2015	Yukon	Chassis	Suspension Control Module																																																												
1	2015	Yukon	Body	Body Control Module																																																												
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2015	Yukon	Body	Passenger Presence Module																																																												
1	2015	Yukon	Body	Instrument Cluster																																																												
1	2015	Yukon	Body	Radio Controls																																																												
1	2015	Yukon	Body	HVAC Controls																																																												
1	2015	Yukon	Body	Radio																																																											
1	2015	Yukon	Body	Amplifier																																																											
1	2015	Yukon	Body	Media Disc Player																																																												
1	2015	Yukon	Body	Human Machine Interface Control Module																																																												
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																												
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																												
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2015	Yukon	Body	HVAC Control Module																																																											
1	2015	Yukon	Body	Liftgate Control Module																																																												
1	2015	Yukon	Body	Keyless Entry Control Module																																																												
1	2015	Yukon	Body	Assist Step Control Module																																																												
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																												
1	2015	Yukon	Body	Parking Assist Control Module																																																												
1	2015	Yukon	Body	Frontview Camera Module																																																												
1	2015	Yukon	Body	Steering Column Lock Control Module																																																												
1	2015	Yukon	Body	Battery Energy Control Module																																																												
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																												
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																												
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																												
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																												
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																												
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																												
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2015	Yukon XL	Chassis	Power Steering Control Module																																																												
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2015	Yukon XL	Chassis	Suspension Control Module																																																												
1	2015	Yukon XL	Body	Body Control Module																																																												
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2015	Yukon XL	Body	Passenger Presence Module																																																												
1	2015	Yukon XL	Body	Instrument Cluster																																																												
1	2015	Yukon XL	Body	Radio Controls																																																												
1	2015	Yukon XL	Body	HVAC Controls																																																												
1	2015	Yukon XL	Body	Radio																																																												
1	2015	Yukon XL	Body	Amplifier																																																												
1	2015	Yukon XL	Body	Media Disc Player																																																												
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																												
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																												
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																												
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2015	Yukon XL	Body	HVAC Control Module																																																												
1	2015	Yukon XL	Body	Liftgate Control Module																																																												
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																												
1	2015	Yukon XL	Body	Assist Step Control Module																																																												
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																												
1	2015	Yukon XL	Body	Parking Assist Control Module																																																												
1	2015	Yukon XL	Body	Frontview Camera Module																																																												
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																												
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2016	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Sierra	Chassis	Parking Brake Control Module																																																										
1	2016	Sierra	Chassis	Power Steering Control Module																																																										
1	2016	Sierra	Chassis	Power Steering Control Module																																																										
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Sierra	Chassis	Suspension Control Module																																																										
1	2016	Sierra	Body	Body Control Module																																																										
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Sierra	Body	Passenger Presence Module																																																										
1	2016	Sierra	Body	Instrument Cluster																																																										
1	2016	Sierra	Body	Radio Controls																																																										
1	2016	Sierra	Body	HVAC Controls																																																										
1	2016	Sierra	Body	Radio (IO3)																																																										
1	2016	Sierra	Body	Radio (IOB)																																																										
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
1	2016	Sierra	Body	Amplifier																																																										
1	2016	Sierra	Body	Media Disc Player																																																										
1	2016	Sierra	Body	Human Machine Interface Control Module																																																										
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																										
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																										
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																										
1	2016	Sierra	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2016	Sierra	Body	Frontview Camera Module																																																										
1	2016	Sierra	Body	Frontview Camera Module																																																										
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2016	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Yukon	Chassis	Parking Brake Control Module																																																										
1	2016	Yukon	Chassis	Power Steering Control Module																																																										
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Yukon	Chassis	Suspension Control Module																																																										
1	2016	Yukon	Body	Body Control Module																																																										
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Yukon	Body	Passenger Presence Module																																																										
1	2016	Yukon	Body	Instrument Cluster																																																										
1	2016	Yukon	Body	Radio Controls																																																										
1	2016	Yukon	Body	HVAC Controls																																																										
1	2016	Yukon	Body	Radio																																																										
1	2016	Yukon	Body	Amplifier																																																										
1	2016	Yukon	Body	Media Disc Player																																																										
1	2016	Yukon	Body	Human Machine Interface Control Module																																																										
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																										
1	2016	Yukon	Body	HVAC Control Module																																																										
1	2016	Yukon	Body	Liftgate Control Module																																																										
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																										
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																										
1	2016	Yukon	Body	Keyless Entry Control Module																																																										
1	2016	Yukon	Body	Assist Step Control Module																																																										
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2016	Yukon	Body	Parking Assist Control Module																																																										
1	2016	Yukon	Body	Frontview Camera Module																																																										
1	2016	Yukon	Body	Steering Column Lock Control Module																																																										
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2016	Yukon XL	Chassis	Power Steering Control Module																																																										
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Yukon XL	Chassis	Suspension Control Module																																																										
1	2016	Yukon XL	Body	Body Control Module																																																										
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
1	2016	Yukon XL	Body	Passenger Presence Module																																																											
1	2016	Yukon XL	Body	Instrument Cluster																																																												
1	2016	Yukon XL	Body	Radio Controls																																																												
1	2016	Yukon XL	Body	HVAC Controls																																																												
1	2016	Yukon XL	Body	Radio																																																												
1	2016	Yukon XL	Body	Amplifier																																																												
1	2016	Yukon XL	Body	Media Disc Player																																																												
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																												
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																												
1	2016	Yukon XL	Body	HVAC Control Module																																																												
1	2016	Yukon XL	Body	Liftgate Control Module																																																												
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																												
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																												
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																												
1	2016	Yukon XL	Body	Assist Step Control Module																																																												
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																												
1	2016	Yukon XL	Body	Parking Assist Control Module																																																												
1	2016	Yukon XL	Body	Frontview Camera Module																																																												
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																												
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																											
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																											
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
2	2011	Sierra	Chassis	Electronic Suspension Control																																																											
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																											
2	2011	Sierra	Body	Amplifier (Bose)																																																											
2	2011	Sierra	Body	Body Control Module																																																											
2	2011	Sierra	Body	Body Control Module (aux.)																																																											
2	2011	Sierra	Body	Digital Radio Receiver																																																											
2	2011	Sierra	Body	Driver Door Switch																																																											
2	2011	Sierra	Body	HVAC Control Module Auto																																																											
2	2011	Sierra	Body	HVAC Control Module Manual																																																											
2	2011	Sierra	Body	Instrument Panel Cluster																																																											
2	2011	Sierra	Body	Memory Seat Module																																																											
2	2011	Sierra	Body	Park Assist Module																																																											
2	2011	Sierra	Body	Passenger Door Switch																																																											
2	2011	Sierra	Body	Passenger Presence System																																																											
2	2011	Sierra	Body	Radio																																																											
2	2011	Sierra	Body	Rear Heated Seat Module																																																											
2	2011	Sierra	Body	Rear HVAC/RSA																																																											
2	2011	Sierra	Body	Supplemental Inflatable Restraint																																																											
2	2011	Sierra	Body	Theft Deterrent Module																																																											
2	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																											
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																											
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																											
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																											
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																											
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																											
2	2011	Sierra Hybrid	Body	Body Control Module																																																											
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																											
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																											
2	2011	Sierra Hybrid	Body	Driver Door Switch																																																											
2	2011	Sierra Hybrid	Body	Heated Seat Module																																																											
2	2011	Sierra Hybrid	Body	HVAC Control Module																																																											
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																											
2	2011	Sierra Hybrid	Body	Park Assist Module																																																											
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																																											
2	2011	Sierra Hybrid	Body	Passenger Presence System																																																											
2	2011	Sierra Hybrid	Body	Radio																																																											
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																											
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																												
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																												
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																												
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
2	2011	Yukon	Chassis	Electronic Brake Control Module																																																												
2	2011	Yukon	Chassis	Electronic Suspension Control																																																												
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																												
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
2	2011	Yukon	Body	Amplifier (Bose)																																																												
2	2011	Yukon	Body	Assist Step Controller																																																												
2	2011	Yukon	Body	Body Control Module																																																												
2	2011	Yukon	Body	Body Control Module (aux.)																																																												
2	2011	Yukon	Body	Digital Radio Receiver																																																												
2	2011	Yukon	Body	Driver Door Switch																																																												
2	2011	Yukon	Body	HVAC Control Module Auto																																																												
2	2011	Yukon	Body	HVAC Control Module Manual																																																												
2	2011	Yukon	Body	Instrument Panel Cluster																																																												
2	2011	Yukon	Body	Left Side Object Detection Module																																																												
2	2011	Yukon	Body	Lift Gate Module																																																												
2	2011	Yukon	Body	Memory Seat Module																																																												
2	2011	Yukon	Body	Park Assist Module																																																												
2	2011	Yukon	Body	Passenger Door Switch																																																												
2	2011	Yukon	Body	Passenger Presence System																																																												
2	2011	Yukon	Body	Radio																																																											
2	2011	Yukon	Body	Rear Heated Seat Module																																																												
2	2011	Yukon	Body	Rear HVAC/RSA																																																												
2	2011	Yukon	Body	Right Side Object Detection Module																																																												
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																																												
2	2011	Yukon	Body	Theft Deterrent Module																																																												
2	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																												
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																												
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																												
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																												
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																												
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																												
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																												
2	2011	Yukon Hybrid	Body	Body Control Module																																																													
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																													
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																													
2	2011	Yukon Hybrid	Body	Driver Door Switch																																																													
2	2011	Yukon Hybrid	Body	Heated Seat Module																																																													
2	2011	Yukon Hybrid	Body	HVAC Control Module																																																													
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																													
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																													
2	2011	Yukon Hybrid	Body	Lift Gate Module																																																													
2	2011	Yukon Hybrid	Body	Park Assist Module																																																													
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																																													
2	2011	Yukon Hybrid	Body	Passenger Presence System																																																													
2	2011	Yukon Hybrid	Body	Radio																																																													
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																													
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																													
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																													
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																													
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																													
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																													
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																													
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																													
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																													
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																													
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																													
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																													
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																													
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																													
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																													
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																													
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																												
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																													
2	2011	Yukon XL	Body	Amplifier (Bose)																																																													
2	2011	Yukon XL	Body	Assist Step Controller																																																													
2	2011	Yukon XL	Body	Body Control Module																																																													
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																													
2	2011	Yukon XL	Body	Digital Radio Receiver																																																													
2	2011	Yukon XL	Body	Driver Door Switch																																																													
2	2011	Yukon XL	Body	HVAC Control Module Auto																																																													
2	2011	Yukon XL	Body	HVAC Control Module Manual																																																													
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																													
2	2011	Yukon XL	Body	Left Side Object Detection Module																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2011	Yukon XL	Body	Lift Gate Module																																																											
2	2011	Yukon XL	Body	Memory Seat Module																																																												
2	2011	Yukon XL	Body	Park Assist Module																																																												
2	2011	Yukon XL	Body	Passenger Door Switch																																																												
2	2011	Yukon XL	Body	Passenger Presence System																																																												
2	2011	Yukon XL	Body	Radio																																																												
2	2011	Yukon XL	Body	Rear Heated Seat Module																																																												
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																												
2	2011	Yukon XL	Body	Right Side Object Detection Module																																																												
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
2	2011	Yukon XL	Body	Theft Deterrent Module																																																												
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
2	2012	Sierra	Chassis	Electronic Suspension Control																																																												
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																												
2	2012	Sierra	Body	Amplifier (Bose)																																																												
2	2012	Sierra	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2012	Sierra	Body	Body Control Module (aux.)																																																										
2	2012	Sierra	Body	Digital Radio Receiver																																																										
2	2012	Sierra	Body	Driver Door Switch																																																										
2	2012	Sierra	Body	HVAC Control Module Auto																																																										
2	2012	Sierra	Body	HVAC Control Module Manual																																																										
2	2012	Sierra	Body	Instrument Panel Cluster																																																										
2	2012	Sierra	Body	Memory Seat Module																																																										
2	2012	Sierra	Body	Park Assist Module																																																										
2	2012	Sierra	Body	Passenger Door Switch																																																										
2	2012	Sierra	Body	Passenger Presence System																																																										
2	2012	Sierra	Body	Radio																																																										
2	2012	Sierra	Body	Navigation Radio																																																										
2	2012	Sierra	Body	Rear Heated Seat Module																																																										
2	2012	Sierra	Body	Rear HVAC/RSA																																																										
2	2012	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra	Body	Theft Deterrent Module																																																										
2	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Sierra Hybrid	Body	Body Control Module																																																										
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2012	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2012	Sierra Hybrid	Body	Park Assist Module																																																										
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2012	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2012	Sierra Hybrid	Body	Radio																																																										
2	2012	Sierra Hybrid	Body	Navigation Radio																																																										
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
2	2012	Yukon	Chassis	Electronic Brake Control Module																																																											
2	2012	Yukon	Chassis	Electronic Suspension Control																																																											
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																											
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
2	2012	Yukon	Body	Amplifier (Bose)																																																											
2	2012	Yukon	Body	Assist Step Controller																																																											
2	2012	Yukon	Body	Body Control Module																																																											
2	2012	Yukon	Body	Body Control Module (aux.)																																																											
2	2012	Yukon	Body	Digital Radio Receiver																																																											
2	2012	Yukon	Body	Driver Door Switch																																																											
2	2012	Yukon	Body	HVAC Control Module Auto																																																											
2	2012	Yukon	Body	HVAC Control Module Manual																																																											
2	2012	Yukon	Body	Instrument Panel Cluster																																																											
2	2012	Yukon	Body	Left Side Object Detection Module																																																											
2	2012	Yukon	Body	Lift Gate Module																																																											
2	2012	Yukon	Body	Memory Seat Module																																																											
2	2012	Yukon	Body	Park Assist Module																																																											
2	2012	Yukon	Body	Passenger Door Switch																																																											
2	2012	Yukon	Body	Passenger Presence System																																																											
2	2012	Yukon	Body	Radio																																																											
2	2012	Yukon	Body	Navigation Radio																																																											
2	2012	Yukon	Body	Rear Heated Seat Module																																																											
2	2012	Yukon	Body	Rear HVAC/RSA																																																											
2	2012	Yukon	Body	Right Side Object Detection Module																																																											
2	2012	Yukon	Body	Supplemental Inflatable Restraint																																																											
2	2012	Yukon	Body	Theft Deterrent Module																																																											
2	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																											
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																											
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																											
2	2012	Yukon Hybrid	Body	Body Control Module																																																											
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																											
2	2012	Yukon Hybrid	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2012	Yukon Hybrid	Body	Heated Seat Module																																																												
2	2012	Yukon Hybrid	Body	HVAC Control Module																																																												
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
2	2012	Yukon Hybrid	Body	Lift Gate Module																																																												
2	2012	Yukon Hybrid	Body	Park Assist Module																																																												
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																																												
2	2012	Yukon Hybrid	Body	Passenger Presence System																																																												
2	2012	Yukon Hybrid	Body	Radio																																																												
2	2012	Yukon Hybrid	Body	Navigation Radio																																																												
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																												
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																												
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																												
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																												
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																												
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																												
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																												
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
2	2012	Yukon XL	Body	Amplifier (Bose)																																																												
2	2012	Yukon XL	Body	Assist Step Controller																																																												
2	2012	Yukon XL	Body	Body Control Module																																																												
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																												
2	2012	Yukon XL	Body	Digital Radio Receiver																																																												
2	2012	Yukon XL	Body	Driver Door Switch																																																												
2	2012	Yukon XL	Body	HVAC Control Module Auto																																																												
2	2012	Yukon XL	Body	HVAC Control Module Manual																																																												
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																												
2	2012	Yukon XL	Body	Left Side Object Detection Module																																																												
2	2012	Yukon XL	Body	Lift Gate Module																																																												
2	2012	Yukon XL	Body	Memory Seat Module																																																												
2	2012	Yukon XL	Body	Park Assist Module																																																												
2	2012	Yukon XL	Body	Passenger Door Switch																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2012	Yukon XL	Body	Passenger Presence System																																																										
2	2012	Yukon XL	Body	Radio																																																										
2	2012	Yukon XL	Body	Navigation Radio																																																										
2	2012	Yukon XL	Body	Rear Heated Seat Module																																																										
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																										
2	2012	Yukon XL	Body	Right Side Object Detection Module																																																										
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
2	2012	Yukon XL	Body	Theft Deterrent Module																																																										
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																																										
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																										
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																										
2	2013	Sierra	Chassis	Electronic Suspension Control																																																										
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra	Body	Amplifier (Bose)																																																										
2	2013	Sierra	Body	Body Control Module																																																										
2	2013	Sierra	Body	Body Control Module (aux.)																																																										
2	2013	Sierra	Body	Digital Radio Receiver																																																										
2	2013	Sierra	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2013	Sierra	Body	HVAC Control Module Auto																																																										
2	2013	Sierra	Body	HVAC Control Module Manual																																																										
2	2013	Sierra	Body	Instrument Panel Cluster																																																										
2	2013	Sierra	Body	Memory Seat Module																																																										
2	2013	Sierra	Body	Park Assist Module																																																										
2	2013	Sierra	Body	Passenger Door Switch																																																										
2	2013	Sierra	Body	Passenger Presence System																																																										
2	2013	Sierra	Body	Radio																																																										
2	2013	Sierra	Body	Navigation Radio																																																										
2	2013	Sierra	Body	Rear Heated Seat Module																																																										
2	2013	Sierra	Body	Rear HVAC/RSA																																																										
2	2013	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2013	Sierra	Body	Theft Deterrent Module																																																										
2	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Sierra Hybrid	Body	Body Control Module																																																										
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2013	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2013	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2013	Sierra Hybrid	Body	Park Assist Module																																																										
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2013	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2013	Sierra Hybrid	Body	Radio																																																										
2	2013	Sierra Hybrid	Body	Navigation Radio																																																										
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2013	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Body	Amplifier (Bose)																																																										
2	2013	Yukon	Body	Assist Step Controller																																																										
2	2013	Yukon	Body	Body Control Module																																																										
2	2013	Yukon	Body	Body Control Module (aux.)																																																										
2	2013	Yukon	Body	Digital Radio Receiver																																																										
2	2013	Yukon	Body	Driver Door Switch																																																										
2	2013	Yukon	Body	HVAC Control Module Auto																																																										
2	2013	Yukon	Body	HVAC Control Module Manual																																																										
2	2013	Yukon	Body	Instrument Panel Cluster																																																										
2	2013	Yukon	Body	Left Side Object Detection Module																																																										
2	2013	Yukon	Body	Lift Gate Module																																																										
2	2013	Yukon	Body	Memory Seat Module																																																										
2	2013	Yukon	Body	Park Assist Module																																																										
2	2013	Yukon	Body	Passenger Door Switch																																																										
2	2013	Yukon	Body	Passenger Presence System																																																										
2	2013	Yukon	Body	Radio																																																										
2	2013	Yukon	Body	Navigation Radio																																																										
2	2013	Yukon	Body	Rear Heated Seat Module																																																										
2	2013	Yukon	Body	Rear HVAC/RSA																																																										
2	2013	Yukon	Body	Right Side Object Detection Module																																																										
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2013	Yukon	Body	Theft Deterrent Module																																																										
2	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2013	Yukon Hybrid	Body	Body Control Module																																																										
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Yukon Hybrid	Body	Driver Door Switch																																																										
2	2013	Yukon Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2013	Yukon Hybrid	Body	HVAC Control Module																																																										
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
2	2013	Yukon Hybrid	Body	Lift Gate Module																																																										
2	2013	Yukon Hybrid	Body	Park Assist Module																																																										
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																																										
2	2013	Yukon Hybrid	Body	Passenger Presence System																																																										
2	2013	Yukon Hybrid	Body	Radio																																																										
2	2013	Yukon Hybrid	Body	Navigation Radio																																																										
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon XL	Body	Amplifier (Bose)																																																										
2	2013	Yukon XL	Body	Assist Step Controller																																																										
2	2013	Yukon XL	Body	Body Control Module																																																										
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																										
2	2013	Yukon XL	Body	Digital Radio Receiver																																																										
2	2013	Yukon XL	Body	Driver Door Switch																																																										
2	2013	Yukon XL	Body	HVAC Control Module Auto																																																										
2	2013	Yukon XL	Body	HVAC Control Module Manual																																																										
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																										
2	2013	Yukon XL	Body	Left Side Object Detection Module																																																										
2	2013	Yukon XL	Body	Lift Gate Module																																																										
2	2013	Yukon XL	Body	Memory Seat Module																																																										
2	2013	Yukon XL	Body	Park Assist Module																																																										
2	2013	Yukon XL	Body	Passenger Door Switch																																																										
2	2013	Yukon XL	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2013	Yukon XL	Body	Radio																																																												
2	2013	Yukon XL	Body	Navigation Radio																																																												
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																												
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																												
2	2013	Yukon XL	Body	Right Side Object Detection Module																																																												
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
2	2013	Yukon XL	Body	Theft Deterrent Module																																																												
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																												
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2014	Sierra	Chassis	Electronic Brake Control Module																																																												
2	2014	Sierra	Chassis	Parking Brake Control Module																																																												
2	2014	Sierra	Chassis	Power Steering Control Module																																																												
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2014	Sierra	Body	Body Control Module																																																												
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2014	Sierra	Body	Passenger Presence Module																																																												
2	2014	Sierra	Body	Instrument Cluster																																																												
2	2014	Sierra	Body	Radio Control																																																												
2	2014	Sierra	Body	HVAC Control																																																												
2	2014	Sierra	Body	Radio																																																												
2	2014	Sierra	Body	Amplifier																																																												
2	2014	Sierra	Body	Media Disc Player																																																												
2	2014	Sierra	Body	Human Machine Interface Control Module																																																												
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																												
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
2	2014	Sierra	Body	Parking Assist Control Module																																																												
2	2014	Sierra	Body	Frontview Camera Module																																																												
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																												
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																												
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																												
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2014	Sierra HD	Chassis	Suspension Control Module																																																										
2	2014	Sierra HD	Body	Body Control Module																																																										
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Sierra HD	Body	Instrument Cluster																																																										
2	2014	Sierra HD	Body	Base Radio																																																										
2	2014	Sierra HD	Body	Navigation Radio																																																										
2	2014	Sierra HD	Body	Uplevel Radio																																																										
2	2014	Sierra HD	Body	Amplifier																																																										
2	2014	Sierra HD	Body	Rear Audio Control Module																																																										
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																										
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																										
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																											V																															
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																											V																															
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																											V																															
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																										
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Sierra HD	Body	Seat Memory Control Module																																																										
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																										
2	2014	Sierra HD	Body	Parking Assist Control Module																				V																																						
2	2014	Sierra HD	Body	Theft Deterrent Module																																																										
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																										
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2014	Yukon	Chassis	Parking Brake Control Module																																																										
2	2014	Yukon	Chassis	Suspension Control Module																																																										
2	2014	Yukon	Body	Body Control Module																																																										
2	2014	Yukon	Body	Auxiliary Body Control Module																																																										
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Yukon	Body	Passenger Presence Module																																																										
2	2014	Yukon	Body	Instrument Cluster																																																										
2	2014	Yukon	Body	Base Radio																																																										
2	2014	Yukon	Body	Navigation Radio																																																										
2	2014	Yukon	Body	Uplevel Radio																																																										
2	2014	Yukon	Body	Amplifier																																																										
2	2014	Yukon	Body	Rear Audio Control Module																																																										
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																										
2	2014	Yukon	Body	Personal Audio Link Control Module																																																										
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																											V																															
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																											V																															
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																											
2	2014	Yukon	Body	Liftgate Control Module																																																												
2	2014	Yukon	Body	Seat Memory Control Module																																																												
2	2014	Yukon	Body	Rear Seat Heating Control Module																																																												
2	2014	Yukon	Body	Assist Step Control Module																																																												
2	2014	Yukon	Body	Right Side Object Detection Control Module																																																												
2	2014	Yukon	Body	Left Side Object Detection Control Module																																																												
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																												
2	2014	Yukon	Body	Parking Assist Control Module																				V																																								
2	2014	Yukon	Body	Theft Deterrent Module																																																												
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																												
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																												
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																												
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																												
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																												
2	2014	Yukon XL	Chassis	Suspension Control Module																																																												
2	2014	Yukon XL	Body	Body Control Module																																																												
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																												
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2014	Yukon XL	Body	Passenger Presence Module																																																												
2	2014	Yukon XL	Body	Instrument Cluster																																																												
2	2014	Yukon XL	Body	Base Radio																																																												
2	2014	Yukon XL	Body	Navigation Radio																																																												
2	2014	Yukon XL	Body	Uplevel Radio																																																												
2	2014	Yukon XL	Body	Amplifier																																																												
2	2014	Yukon XL	Body	Rear Audio Control Module																																																												
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																												
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																												
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																												
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																											V																																	
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																											V																																	
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																												
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																												
2	2014	Yukon XL	Body	Liftgate Control Module																																																												
2	2014	Yukon XL	Body	Seat Memory Control Module																																																												
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																												
2	2014	Yukon XL	Body	Assist Step Control Module																																																												
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																												
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																												
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																												
2	2014	Yukon XL	Body	Parking Assist Control Module																				V																																								
2	2014	Yukon XL	Body	Theft Deterrent Module																																																												
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Sierra	Chassis	Electronic Brake Control Module																																																										
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Sierra	Chassis	Power Steering Control Module																																																										
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Sierra	Chassis	Suspension Control Module																																																										
2	2015	Sierra	Body	Body Control Module																																																										
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Sierra	Body	Passenger Presence Module																																																										
2	2015	Sierra	Body	Instrument Cluster																																																										
2	2015	Sierra	Body	Radio Controls																																																										
2	2015	Sierra	Body	HVAC Controls																																																										
2	2015	Sierra	Body	Radio																																																										
2	2015	Sierra	Body	Amplifier																																																										
2	2015	Sierra	Body	Media Disc Player																																																										
2	2015	Sierra	Body	Human Machine Interface Control Module																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2015	Sierra	Body	Parking Assist Control Module																																																										
2	2015	Sierra	Body	Frontview Camera Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																										
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																										
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																										
2	2015	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Yukon	Chassis	Parking Brake Control Module																																																										
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																										
2	2015	Yukon	Chassis	Power Steering Control Module																																																										
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Yukon	Chassis	Suspension Control Module																																																										
2	2015	Yukon	Body	Body Control Module																																																										
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Yukon	Body	Passenger Presence Module																																																										
2	2015	Yukon	Body	Instrument Cluster																																																										
2	2015	Yukon	Body	Radio Controls																																																										
2	2015	Yukon	Body	HVAC Controls																																																										
2	2015	Yukon	Body	Radio																																																										
2	2015	Yukon	Body	Amplifier																																																										
2	2015	Yukon	Body	Media Disc Player																																																										
2	2015	Yukon	Body	Human Machine Interface Control Module																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Yukon	Body	HVAC Control Module																																																										
2	2015	Yukon	Body	Liftgate Control Module																																																										
2	2015	Yukon	Body	Keyless Entry Control Module																																																										
2	2015	Yukon	Body	Assist Step Control Module																																																										
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																										
2	2015	Yukon	Body	Parking Assist Control Module																																																										
2	2015	Yukon	Body	Frontview Camera Module																																																										
2	2015	Yukon	Body	Steering Column Lock Control Module																																																										
2	2015	Yukon	Body	Battery Energy Control Module																																																										
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																											
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																												
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																												
2	2015	Yukon XL	Chassis	Power Steering Control Module																																																												
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2015	Yukon XL	Chassis	Suspension Control Module																																																												
2	2015	Yukon XL	Body	Body Control Module																																																												
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2015	Yukon XL	Body	Passenger Presence Module																																																												
2	2015	Yukon XL	Body	Instrument Cluster																																																												
2	2015	Yukon XL	Body	Radio Controls																																																												
2	2015	Yukon XL	Body	HVAC Controls																																																												
2	2015	Yukon XL	Body	Radio																																																												
2	2015	Yukon XL	Body	Amplifier																																																												
2	2015	Yukon XL	Body	Media Disc Player																																																												
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																												
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																												
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																												
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2015	Yukon XL	Body	HVAC Control Module																																																												
2	2015	Yukon XL	Body	Liftgate Control Module																																																												
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																												
2	2015	Yukon XL	Body	Assist Step Control Module																																																												
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																												
2	2015	Yukon XL	Body	Parking Assist Control Module																																																												
2	2015	Yukon XL	Body	Frontview Camera Module																																																												
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																												
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																												
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																												
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																												
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																												
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																												
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																												
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																												
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2016	Sierra	Chassis	Electronic Brake Control Module																																																											
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																											
2	2016	Sierra	Chassis	Parking Brake Control Module																																																											
2	2016	Sierra	Chassis	Power Steering Control Module																																																											
2	2016	Sierra	Chassis	Power Steering Control Module																																																											
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2016	Sierra	Chassis	Suspension Control Module																																																											
2	2016	Sierra	Body	Body Control Module																																																											
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2016	Sierra	Body	Passenger Presence Module																																																											
2	2016	Sierra	Body	Instrument Cluster																																																											
2	2016	Sierra	Body	Radio Controls																																																											
2	2016	Sierra	Body	HVAC Controls																																																											
2	2016	Sierra	Body	Radio (IO3)																																																											
2	2016	Sierra	Body	Radio (IOB)																																																											
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																											
2	2016	Sierra	Body	Amplifier																																																											
2	2016	Sierra	Body	Media Disc Player																																																											
2	2016	Sierra	Body	Human Machine Interface Control Module																																																											
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																											
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																											
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																											
2	2016	Sierra	Body	Parking Assist Control Module																																																											
2	2016	Sierra	Body	Frontview Camera Module																																																											
2	2016	Sierra	Body	Frontview Camera Module																																																											
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2016	Yukon	Chassis	Electronic Brake Control Module																																																											
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																											
2	2016	Yukon	Chassis	Parking Brake Control Module																																																											
2	2016	Yukon	Chassis	Power Steering Control Module																																																											
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2016	Yukon	Chassis	Suspension Control Module																																																											
2	2016	Yukon	Body	Body Control Module																																																											
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2016	Yukon	Body	Passenger Presence Module																																																											
2	2016	Yukon	Body	Instrument Cluster																																																											
2	2016	Yukon	Body	Radio Controls																																																											
2	2016	Yukon	Body	HVAC Controls																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
2	2016	Yukon	Body	Radio																																																										
2	2016	Yukon	Body	Amplifier																																																										
2	2016	Yukon	Body	Media Disc Player																																																										
2	2016	Yukon	Body	Human Machine Interface Control Module																																																										
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																										
2	2016	Yukon	Body	HVAC Control Module																																																										
2	2016	Yukon	Body	Liftgate Control Module																																																										
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																										
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																										
2	2016	Yukon	Body	Keyless Entry Control Module																																																										
2	2016	Yukon	Body	Assist Step Control Module																																																										
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																										
2	2016	Yukon	Body	Parking Assist Control Module																																																										
2	2016	Yukon	Body	Frontview Camera Module																																																										
2	2016	Yukon	Body	Steering Column Lock Control Module																																																										
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																										
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																										
2	2016	Yukon XL	Chassis	Power Steering Control Module																																																										
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2016	Yukon XL	Chassis	Suspension Control Module																																																										
2	2016	Yukon XL	Body	Body Control Module																																																										
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2016	Yukon XL	Body	Passenger Presence Module																																																										
2	2016	Yukon XL	Body	Instrument Cluster																																																										
2	2016	Yukon XL	Body	Radio Controls																																																										
2	2016	Yukon XL	Body	HVAC Controls																																																										
2	2016	Yukon XL	Body	Radio																																																										
2	2016	Yukon XL	Body	Amplifier																																																										
2	2016	Yukon XL	Body	Media Disc Player																																																										
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																										
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																										
2	2016	Yukon XL	Body	HVAC Control Module																																																										
2	2016	Yukon XL	Body	Liftgate Control Module																																																										
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																										
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																										
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																										
2	2016	Yukon XL	Body	Assist Step Control Module																																																										
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																										
2	2016	Yukon XL	Body	Parking Assist Control Module																																																										
2	2016	Yukon XL	Body	Frontview Camera Module																																																										
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																										
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
5	2011	ALL	Chassis	Electronic Brake Control Module																																																													
5	2011	ALL	Body	Body Control Module																																																													
5	2011	ALL	Body	Digital Radio Receiver																																																													
5	2011	ALL	Body	Generator Battery Control Module																																																													
5	2011	ALL	Body	Instrument Panel Cluster																																																													
5	2011	ALL	Body	Passenger Presence System																																																													
5	2011	ALL	Body	Personal Audio Link Module																																																													
5	2011	ALL	Body	Base Radio																																																													
5	2011	ALL	Body	Uplevel Radio																																																													
5	2011	ALL	Body	Supplemental Inflatable Restraint																																																													
5	2011	ALL	Body	Theft Deterrent Module																																																													
5	2011	ALL	Body	Vehicle Comm. Interface Module																																																													
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																													
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																													
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																													
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																													
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																													
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																													
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																													
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																													
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																													
5	2012	ALL	Chassis	Electronic Brake Control Module																																																													
5	2012	ALL	Body	Body Control Module																																																													
5	2012	ALL	Body	Digital Radio Receiver																																																													
5	2012	ALL	Body	Generator Battery Control Module																																																													
5	2012	ALL	Body	Instrument Panel Cluster																																																													
5	2012	ALL	Body	Passenger Presence System																																																													
5	2012	ALL	Body	Personal Audio Link Module																																																													
5	2012	ALL	Body	Base Radio																																																													
5	2012	ALL	Body	Uplevel Radio																																																													
5	2012	ALL	Body	Supplemental Inflatable Restraint																																																													
5	2012	ALL	Body	Theft Deterrent Module																																																													
5	2012	ALL	Body	Vehicle Comm. Interface Module																																																													
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																													
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																													
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																													
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																													
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																													
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
5	2015	Canyon	Powertrain	Chassis Control Module																																																													
5	2015	Canyon	Powertrain	Transfer Case Control Module																																																													
5	2015	Canyon	Chassis	Electronic Brake Control Module																																																													
5	2015	Canyon	Chassis	Power Steering Control Module																																																													
5	2015	Canyon	Body	Body Control Module																																																													

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
5	2015	Canyon	Body	Passenger Presence Module																																																										
5	2015	Canyon	Body	Radio																																																										
5	2015	Canyon	Body	Amplifier																																																										
5	2015	Canyon	Body	Human Machine Interface Control Module																																																										
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																																										
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
5	2015	Canyon	Body	Parking Assist Control Module																																																										
5	2015	Canyon	Body	Frontview Camera Module																																																										
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
5	2016	Canyon	Powertrain	Transfer Case Control Module																																																										
5	2016	Canyon	Chassis	Electronic Brake Control Module																																																										
5	2016	Canyon	Chassis	Power Steering Control Module																																																										
5	2016	Canyon	Body	Body Control Module																																																										
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
5	2016	Canyon	Body	Passenger Presence Module																																																										
5	2016	Canyon	Body	Trailer Interface Control Module																																																										
5	2016	Canyon	Body	Radio																																																										
5	2016	Canyon	Body	Amplifier																																																										
5	2016	Canyon	Body	Human Machine Interface Control Module																																																										
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																																										
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
5	2016	Canyon	Body	Frontview Camera Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
6	2011	ALL	Chassis	Electronic Brake Control Module																																																										
6	2011	ALL	Body	Body Control Module																																																										
6	2011	ALL	Body	Digital Radio Receiver																																																										
6	2011	ALL	Body	Generator Battery Control Module																																																										
6	2011	ALL	Body	Instrument Panel Cluster																																																										
6	2011	ALL	Body	Passenger Presence System																																																										
6	2011	ALL	Body	Personal Audio Link Module																																																										
6	2011	ALL	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
6	2011	ALL	Body	Uplevel Radio																																																											
6	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
6	2011	ALL	Body	Theft Deterrent Module																																																											
6	2011	ALL	Body	Vehicle Comm. Interface Module																																																											
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
6	2012	ALL	Chassis	Electronic Brake Control Module																																																												
6	2012	ALL	Body	Body Control Module																																																												
6	2012	ALL	Body	Digital Radio Receiver																																																												
6	2012	ALL	Body	Generator Battery Control Module																																																											
6	2012	ALL	Body	Instrument Panel Cluster																																																											
6	2012	ALL	Body	Passenger Presence System																																																											
6	2012	ALL	Body	Personal Audio Link Module																																																											
6	2012	ALL	Body	Base Radio																																																											
6	2012	ALL	Body	Uplevel Radio																																																											
6	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
6	2012	ALL	Body	Theft Deterrent Module																																																											
6	2012	ALL	Body	Vehicle Comm. Interface Module																																																											
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
6	2015	Canyon	Powertrain	Chassis Control Module																																																											
6	2015	Canyon	Powertrain	Transfer Case Control Module																																																											
6	2015	Canyon	Chassis	Electronic Brake Control Module																																																											
6	2015	Canyon	Chassis	Power Steering Control Module																																																											
6	2015	Canyon	Body	Body Control Module																																																											
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
6	2015	Canyon	Body	Passenger Presence Module																																																											
6	2015	Canyon	Body	Radio																																																										
6	2015	Canyon	Body	Amplifier																																																										
6	2015	Canyon	Body	Human Machine Interface Control Module																																																										
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																																										
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																									
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																									
6	2015	Canyon	Body	Parking Assist Control Module																																																								
6	2015	Canyon	Body	Frontview Camera Module																																																								
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																									
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																												
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
6	2016	Canyon	Powertrain	Transfer Case Control Module																																																												
6	2016	Canyon	Chassis	Electronic Brake Control Module																																																												
6	2016	Canyon	Chassis	Power Steering Control Module																																																												
6	2016	Canyon	Body	Body Control Module																																																												
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
6	2016	Canyon	Body	Passenger Presence Module																																																												
6	2016	Canyon	Body	Trailer Interface Control Module																																																												
6	2016	Canyon	Body	Radio																																																												
6	2016	Canyon	Body	Amplifier																																																												
6	2016	Canyon	Body	Human Machine Interface Control Module																																																												
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																																												
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																												
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																												
6	2016	Canyon	Body	Frontview Camera Module																																																												
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2011	Express/Savana	Body	Body Control Module																																																												
7	2011	Express/Savana	Body	Digital Radio Receiver																																																												
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																												
7	2011	Express/Savana	Body	Passenger Presence System																																																												
7	2011	Express/Savana	Body	Radio																																																												
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
7	2011	Express/Savana	Body	Rollover Sensor																																																												
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
7	2011	Express/Savana	Body	Theft Deterrent Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2011	Express Access/Savana Pro	Body	Body Control Module																																																										
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																										
7	2011	Express Access/Savana Pro	Body	Radio																																																										
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																										
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2012	Express/Savana	Body	Body Control Module																																																										
7	2012	Express/Savana	Body	Digital Radio Receiver																																																										
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																										
7	2012	Express/Savana	Body	Passenger Presence System																																																										
7	2012	Express/Savana	Body	Radio																																																										
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
7	2012	Express/Savana	Body	Rollover Sensor																																																										
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
7	2012	Express/Savana	Body	Theft Deterrent Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																										
7	2012	Express Access/Savana Pro	Body	Radio																																																										
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2013	Express/Savana	Body	Body Control Module																																																										
7	2013	Express/Savana	Body	Digital Radio Receiver																																																										
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
7	2013	Express/Savana	Body	Passenger Presence System																																																										
7	2013	Express/Savana	Body	Radio																																																										
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
7	2013	Express/Savana	Body	Rollover Sensor																																																										
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
7	2013	Express/Savana	Body	Theft Deterrent Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2013	Express Access/Savana Pro	Body	Body Control Module																																																										
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
7	2013	Express Access/Savana Pro	Body	Radio																																																										
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2014	Savana	Chassis	Electronic Brake Control Module																																																										
7	2014	Savana	Body	Body Control Module																																																										
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2014	Savana	Body	Passenger Presence Module																																																										
7	2014	Savana	Body	Rollover Sensor Module																																																										
7	2014	Savana	Body	Instrument Cluster																																																										
7	2014	Savana	Body	Chime Alarm Control Module																																																										
7	2014	Savana	Body	Base Radio																																																										
7	2014	Savana	Body	Navigation Radio																																																										
7	2014	Savana	Body	Uplevel Radio																																																										
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
7	2014	Savana	Body	Auxiliary Heater Control Module																																																											
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																											
7	2014	Savana	Body	Parking Assist Control Module																																																											
7	2014	Savana	Body	Theft Deterrent Module																																																											
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
7	2015	Savana	Chassis	Electronic Brake Control Module																																																											
7	2015	Savana	Body	Body Control Module																																																											
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
7	2015	Savana	Body	Rollover Sensor Module																																																											
7	2015	Savana	Body	Instrument Cluster																																																											
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																											
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											
7	2015	Savana	Body	Auxiliary Heater Control Module																																																											
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																											
7	2015	Savana	Body	Parking Assist Control Module																																																											
7	2015	Savana	Body	Theft Deterrent Module																																																											
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																											
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
7	2016	Savana	Chassis	Electronic Brake Control Module																																																											
7	2016	Savana	Body	Body Control Module																																																											
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
7	2016	Savana	Body	Instrument Cluster																																																											
7	2016	Savana	Body	Chime Alarm Control Module																																																											
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																											
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																											
7	2016	Savana	Body	Auxiliary Heater Control Module																																																											
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																											
7	2016	Savana	Body	Parking Assist Control Module																																																											
7	2016	Savana	Body	Theft Deterrent Module																																																											
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2011	Express/Savana	Body	Body Control Module																																																										
8	2011	Express/Savana	Body	Digital Radio Receiver																																																										
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
8	2011	Express/Savana	Body	Passenger Presence System																																																										
8	2011	Express/Savana	Body	Radio																																																										
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
8	2011	Express/Savana	Body	Rollover Sensor																																																										
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
8	2011	Express/Savana	Body	Theft Deterrent Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2011	Express Access/Savana Pro	Body	Body Control Module																																																										
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																										
8	2011	Express Access/Savana Pro	Body	Radio																																																										
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																										
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2012	Express/Savana	Body	Body Control Module																																																										
8	2012	Express/Savana	Body	Digital Radio Receiver																																																										
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																										
8	2012	Express/Savana	Body	Passenger Presence System																																																										
8	2012	Express/Savana	Body	Radio																																																										
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
8	2012	Express/Savana	Body	Rollover Sensor																																																										
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
8	2012	Express/Savana	Body	Theft Deterrent Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																										
8	2012	Express Access/Savana Pro	Body	Radio																																																										
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2013	Express/Savana	Body	Body Control Module																																																										
8	2013	Express/Savana	Body	Digital Radio Receiver																																																										
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
8	2013	Express/Savana	Body	Navigation Radio																																																										
8	2013	Express/Savana	Body	Park Assist Module																																																										
8	2013	Express/Savana	Body	Passenger Presence System																																																										
8	2013	Express/Savana	Body	Radio																																																										
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
8	2013	Express/Savana	Body	Rollover Sensor																																																										
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
8	2013	Express/Savana	Body	Theft Deterrent Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2013	Express Access/Savana Pro	Body	Body Control Module																																																										
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
8	2013	Express Access/Savana Pro	Body	Radio																																																										
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
8	2014	Savana	Chassis	Electronic Brake Control Module																																																										
8	2014	Savana	Body	Body Control Module																																																										
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
8	2014	Savana	Body	Passenger Presence Module																																																										
8	2014	Savana	Body	Rollover Sensor Module																																																										
8	2014	Savana	Body	Instrument Cluster																																																										
8	2014	Savana	Body	Chime Alarm Control Module																																																										
8	2014	Savana	Body	Base Radio																																																										
8	2014	Savana	Body	Navigation Radio																																																										
8	2014	Savana	Body	Uplevel Radio																																																										
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
8	2014	Savana	Body	Auxiliary Heater Control Module																																																										
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
8	2014	Savana	Body	Parking Assist Control Module																																																										
8	2014	Savana	Body	Theft Deterrent Module																																																										
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
8	2015	Savana	Chassis	Electronic Brake Control Module																																																										
8	2015	Savana	Body	Body Control Module																																																										
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
8	2015	Savana	Body	Rollover Sensor Module																																																										
8	2015	Savana	Body	Instrument Cluster																																																										
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
8	2015	Savana	Body	Auxiliary Heater Control Module																																																										
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
8	2015	Savana	Body	Parking Assist Control Module																																																										
8	2015	Savana	Body	Theft Deterrent Module																																																										
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
8	2016	Savana	Chassis	Electronic Brake Control Module																																																										
8	2016	Savana	Body	Body Control Module																																																										
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
8	2016	Savana	Body	Instrument Cluster																																																										
8	2016	Savana	Body	Chime Alarm Control Module																																																										
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
8	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
8	2016	Savana	Body	Auxiliary Heater Control Module																																																										
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
8	2016	Savana	Body	Parking Assist Control Module																																																										
8	2016	Savana	Body	Theft Deterrent Module																																																										
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																										
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																										
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																										
ALL	2004	ALL	Chassis	ABS																																																										
ALL	2004	ALL	Chassis	Air Suspension																																																										
ALL	2004	ALL	Body	Amplifier (Bose)																																																										
ALL	2004	ALL	Body	Body Control Module																																																										
ALL	2004	ALL	Body	Digital Radio Receiver																																																										
ALL	2004	ALL	Body	Driver Door Module																																																										
ALL	2004	ALL	Body	Driver Seat Module																																																										
ALL	2004	ALL	Body	Heating and Air Conditioning																																																										
ALL	2004	ALL	Body	Instrument Panel Cluster																																																										
ALL	2004	ALL	Body	OnStar																																																										
ALL	2004	ALL	Body	Passenger Door Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
ALL	2004	ALL	Body	Uplevel Radio																																																										
ALL	2004	ALL	Body	Navigation Radio																																																										
ALL	2004	ALL	Body	Rear Seat Audio																																																										
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																										
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																										
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																										
ALL	2005	ALL	Chassis	ABS																																																										
ALL	2005	ALL	Chassis	Air Suspension																																																										
ALL	2005	ALL	Body	Body Control Module																																																										
ALL	2005	ALL	Body	Digital Radio Receiver																																																										
ALL	2005	ALL	Body	Driver Door Module (SUV)																																																										
ALL	2005	ALL	Body	Driver Door Module (SUT)																																																										
ALL	2005	ALL	Body	Driver Seat Module																																																										
ALL	2005	ALL	Body	Heating and Air Conditioning																																																										
ALL	2005	ALL	Body	Instrument Panel Cluster																																																										
ALL	2005	ALL	Body	Passenger Door Module																																																										
ALL	2005	ALL	Body	Uplevel Radio																																																										
ALL	2005	ALL	Body	Navigation Radio																																																										
ALL	2005	ALL	Body	Rear Seat Audio																																																										
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																										
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																										
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																										
ALL	2006	H2	Chassis	ABS																																																										
ALL	2006	H2	Chassis	Air Suspension																																																										
ALL	2006	H2	Body	Body Control Module																																																										
ALL	2006	H2	Body	Digital Radio Receiver																																																										
ALL	2006	H2	Body	Driver Door Module (SUV)																																																										
ALL	2006	H2	Body	Driver Door Module (SUT)																																																										
ALL	2006	H2	Body	Driver Seat Module																																																										
ALL	2006	H2	Body	Heating and Air Conditioning																																																										
ALL	2006	H2	Body	Instrument Panel Cluster																																																										
ALL	2006	H2	Body	Passenger Door Module																																																										
ALL	2006	H2	Body	Uplevel Radio																																																										
ALL	2006	H2	Body	Navigation Radio																																																										
ALL	2006	H2	Body	Rear Seat Audio																																																										
ALL	2006	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2006	H3	Powertrain	Engine Control Module																																																										
ALL	2006	H3	Powertrain	Transmission Control Module																																																										
ALL	2006	H3	Powertrain	Transfer Case Control Module																																																										
ALL	2006	H3	Chassis	Antilock Brake System																																																										
ALL	2006	H3	Body	Body Control Module																																																										
ALL	2006	H3	Body	Digital Radio Receiver																																																										
ALL	2006	H3	Body	Instrument Panel Cluster																																																										
ALL	2006	H3	Body	Uplevel Radio																																																										
ALL	2006	H3	Body	Navigation Radio																																																										
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																										
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																										
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
ALL	2007	H2	Chassis	ABS																																																											
ALL	2007	H2	Chassis	Air Suspension																																																												
ALL	2007	H2	Body	Amplifier (Bose)																																																												
ALL	2007	H2	Body	Body Control Module																																																												
ALL	2007	H2	Body	Digital Radio Receiver																																																												
ALL	2007	H2	Body	Driver Door Module (SUV)																																																												
ALL	2007	H2	Body	Driver Door Module (SUT)																																																												
ALL	2007	H2	Body	Driver Seat Module																																																												
ALL	2007	H2	Body	HVAC Control Module																																																												
ALL	2007	H2	Body	Instrument Panel Cluster																																																												
ALL	2007	H2	Body	Passenger Door Module																																																												
ALL	2007	H2	Body	Uplevel Radio																																																												
ALL	2007	H2	Body	Navigation Radio																																																												
ALL	2007	H2	Body	Rear Seat Audio																																																												
ALL	2007	H2	Body	Supplemental Inflatable Restraint																																																												
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																																												
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																												
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																												
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																												
ALL	2007	H3	Chassis	EBCM																																																												
ALL	2007	H3	Body	Body Control Module (5GT)																																																												
ALL	2007	H3	Body	Body Control Module (ADM)																																																												
ALL	2007	H3	Body	Digital Radio Receiver																																																												
ALL	2007	H3	Body	Generator Battery Control Module																																																												
ALL	2007	H3	Body	Instrument Panel Cluster																																																												
ALL	2007	H3	Body	Personal Audio Link Module																																																												
ALL	2007	H3	Body	Uplevel Radio																																																												
ALL	2007	H3	Body	Navigation Radio																																																												
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																																												
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																												
ALL	2008	H2	Chassis	Air SCM																																																												
ALL	2008	H2	Chassis	EBCM																																																												
ALL	2008	H2	Body	Amplifier (Bose)																																																												
ALL	2008	H2	Body	Body Control Module																																																												
ALL	2008	H2	Body	Digital Radio Receiver																																																												
ALL	2008	H2	Body	Driver Door Switch																																																												
ALL	2008	H2	Body	HVAC Control Module																																																												
ALL	2008	H2	Body	Instrument Panel Cluster																																																												
ALL	2008	H2	Body	Memory Seat Module																																																												
ALL	2008	H2	Body	Passenger Door Switch																																																												
ALL	2008	H2	Body	Radio																																																												
ALL	2008	H2	Body	Rear Heated Seat Module																																																												
ALL	2008	H2	Body	Rear HVAC/RSA																																																												
ALL	2008	H2	Body	Rollover Sensor																																																												
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																																												
ALL	2008	H2	Body	Theft Deterrent Module																																																												
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																																												

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																																										
ALL	2008	H3	Chassis	EBCM																																																										
ALL	2008	H3	Body	Body Control Module (5GT)																																																										
ALL	2008	H3	Body	Body Control Module (ADM)																																																										
ALL	2008	H3	Body	Digital Radio Receiver																																																										
ALL	2008	H3	Body	Generator Battery Control Module																																																										
ALL	2008	H3	Body	Instrument Panel Cluster																																																										
ALL	2008	H3	Body	Personal Audio Link Module																																																										
ALL	2008	H3	Body	Uplevel Radio																																																										
ALL	2008	H3	Body	Navigation Radio																																																										
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	H3	Body	Theft Deterrent Module																																																										
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2009	H2	Chassis	Air SCM																																																										
ALL	2009	H2	Chassis	EBCM																																																										
ALL	2009	H2	Body	Amplifier (Bose)																																																										
ALL	2009	H2	Body	Body Control Module																																																										
ALL	2009	H2	Body	Digital Radio Receiver																																																										
ALL	2009	H2	Body	Driver Door Switch																																																										
ALL	2009	H2	Body	HVAC Control Module																																																										
ALL	2009	H2	Body	Instrument Panel Cluster																																																										
ALL	2009	H2	Body	Memory Seat Module																																																										
ALL	2009	H2	Body	Passenger Door Switch																																																										
ALL	2009	H2	Body	Radio																																																										
ALL	2009	H2	Body	Rear Heated Seat Module																																																										
ALL	2009	H2	Body	Rear HVAC/RSA																																																										
ALL	2009	H2	Body	Rollover Sensor																																																										
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	H2	Body	Theft Deterrent Module																																																										
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2009	H3	Chassis	EBCM																																																										
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																																										
ALL	2009	H3	Body	Body Control Module (ADM)																																																										
ALL	2009	H3	Body	Digital Radio Receiver																																																										
ALL	2009	H3	Body	Generator Battery Control Module																																																										
ALL	2009	H3	Body	Instrument Panel Cluster																																																										
ALL	2009	H3	Body	Personal Audio Link Module																																																										
ALL	2009	H3	Body	Uplevel Radio																																																										
ALL	2009	H3	Body	Navigation Radio																																																										
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	H3	Body	Theft Deterrent Module																																																										
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2010	H2	Chassis	Air SCM																																																										
ALL	2010	H2	Chassis	EBCM																																																										
ALL	2010	H2	Body	Amplifier (Bose)																																																										
ALL	2010	H2	Body	Body Control Module																																																										
ALL	2010	H2	Body	Digital Radio Receiver																																																										
ALL	2010	H2	Body	Driver Door Switch																																																										
ALL	2010	H2	Body	HVAC Control Module																																																										
ALL	2010	H2	Body	Instrument Panel Cluster																																																										
ALL	2010	H2	Body	Memory Seat Module																																																										
ALL	2010	H2	Body	Passenger Door Switch																																																										
ALL	2010	H2	Body	Personal Audio Link Module																																																										
ALL	2010	H2	Body	Radio																																																										
ALL	2010	H2	Body	Rear Heated Seat Module																																																										
ALL	2010	H2	Body	Rear HVAC/RSA																																																										
ALL	2010	H2	Body	Rollover Sensor																																																										
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	H2	Body	Theft Deterrent Module																																																										
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2010	H3	Chassis	EBCM																																																										
ALL	2010	H3	Body	Body Control Module																																																										
ALL	2010	H3	Body	Digital Radio Receiver																																																										
ALL	2010	H3	Body	Generator Battery Control Module																																																										
ALL	2010	H3	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Idle Speed Control Reset	ECM Reset	Intrusion Alarm Data	Vehicle Status Data	Parking Assist Sensor Learn	Transmission Solenoid Valves Calibration Preset	CO Adjust	EV Range Reset	Hybrid/EV Battery Interface Control Module Data	Voltage Data 4	Voltage Data 5	Voltage Data 6	Voltage Data 7	Voltage Data 8	Tire Pressure Monitoring System Data - Front	Tire Pressure Monitoring System Data - Rear	Folding Top Inhibit Data - Last Inhibited Cycle	Folding Top Data - History	Exhaust Flow Control Valve Data	Parking Assist Disable History Data	Vehicle Direction Camera Learn	Exhaust Flow Control Valve Learn	Rear Suspension Position Sensor Trim Height	Front Suspension Position Sensor Trim Height	Mirror Memory Data	Active Grille Data	HVAC Afterblow Configuration	Instrument Cluster	Reset Functions	Learn Functions	System Configuration Data	Inspection/Maintenance Data	Clutch Position Learn	Throttle Position Learn	Charging Data	IAC Data	Fuel Trim 1	Fuel Trim 2	Reset ECM	IAC Reset	HO2S	Transmission Data 1	Transmission Data 2	Engine Data (Alt. Fuel)	Mileage/Time Data	Door Lock Data	Lamp Status	ISC System	CO Adjust Value (leaded fuel only)	SIR Data	Reset TPS Learn Value	Exh. Aftertreatment	Cranking Speed Test	Idle Speed Test	Fuel Quantity Test	DPF Reset Replace Press. Sensor
ALL	2010	H3	Body	Personal Audio Link Module																																																											
ALL	2010	H3	Body	Uplevel Radio																																																												
ALL	2010	H3	Body	Navigation Radio																																																												
ALL	2010	H3	Body	Supplemental Inflatable Restraint																																																												
ALL	2010	H3	Body	Theft Deterrent Module																																																												
ALL	2010	H3	Body	Vehicle Comm. Interface Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																										
C	2004	ALL	Body	CD Changer																																																										
C	2004	ALL	Body	Chime																																																										
C	2004	ALL	Body	Driver Door Module																																																										
C	2004	ALL	Body	Driver Seat Module																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2004	ALL	Body	Instrument Panel Cluster																																																										
C	2004	ALL	Body	OnStar																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2004	ALL	Body	Passenger Door Module																																																									
C	2004	ALL	Body	Passenger Presence System																																																									
C	2004	ALL	Body	Radio Base																																																									
C	2004	ALL	Body	Radio Uplevel																																																									
C	2004	ALL	Body	Radio Navigation																																																									
C	2004	ALL	Body	Rear Aux. Climate Module																																																										
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																										
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2004	ALL	Body	Vehicle Theft Deterrent																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2005	ALL	Chassis	ESC																																																									
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2005	ALL	Chassis	VSES																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2005	ALL	Body	Amplifier (Bose)																																																									
C	2005	ALL	Body	Body Control Module																																																									
C	2005	ALL	Body	CD Changer																																																									
C	2005	ALL	Body	Chime																																																									
C	2005	ALL	Body	Disc Player and Video Display																																																									
C	2005	ALL	Body	Driver Door Module																																																									
C	2005	ALL	Body	Driver Seat Module																																																									
C	2005	ALL	Body	Generator Battery Control Module																																																									
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																									
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																									
C	2005	ALL	Body	Instrument Panel Cluster																																																									
C	2005	ALL	Body	Passenger Door Module																																																									
C	2005	ALL	Body	Passenger Presence System																																																									
C	2005	ALL	Body	Base Radio																																																									
C	2005	ALL	Body	Uplevel Radio																																																									
C	2005	ALL	Body	Navigation Radio																																																									
C	2005	ALL	Body	Rear Aux. Climate Module																																																									
C	2005	ALL	Body	Rear HVAC																																																									
C	2005	ALL	Body	Rear Seat Audio																																																									
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																									
C	2005	ALL	Body	Vehicle Theft Deterrent																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																							V			
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																									
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																				V			
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																							
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																							
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																							
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																							
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																							
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																							
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																							
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																							
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																							
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																						
C	2006	ALL	Chassis	ESC																																																						
C	2006	ALL	Chassis	Tire Pressure Monitor																																																						
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																						
C	2006	ALL	Chassis	VSES																																																						
C	2006	ALL	Body	Amplifier (Bose)																																																						
C	2006	ALL	Body	Body Control Module																																																						
C	2006	ALL	Body	CD Changer																																																						
C	2006	ALL	Body	Chime																																																						
C	2006	ALL	Body	Disc Player and Video Display																																																						
C	2006	ALL	Body	Driver Door Module																																																						
C	2006	ALL	Body	Driver Seat Module																																																						
C	2006	ALL	Body	Generator Battery Control Module																																																						
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																						
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																						
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																						
C	2006	ALL	Body	Instrument Panel Cluster																																																						
C	2006	ALL	Body	Passenger Door Module																																																						
C	2006	ALL	Body	Passenger Presence System																																																						
C	2006	ALL	Body	Base Radio																																																						
C	2006	ALL	Body	Uplevel Radio																																																						
C	2006	ALL	Body	Navigation Radio																																																						
C	2006	ALL	Body	Rear Aux. Climate Module																																																						
C	2006	ALL	Body	Rear HVAC																																																						
C	2006	ALL	Body	Rear Seat Audio																																																						
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																						
C	2006	ALL	Body	Vehicle Theft Deterrent																																																						
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																						
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																						
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																						
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																						
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																						
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																						
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																						
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																						
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																						
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																						
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																						
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																						
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																						
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																						

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V												V			V				
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																								
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2007	Sierra	Chassis	Electronic Suspension Control																																																								
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																								
C	2007	Sierra	Body	Amplifier (Bose)																																																								
C	2007	Sierra	Body	Body Control Module																																																								
C	2007	Sierra	Body	Body Control Module (aux.)																																																								
C	2007	Sierra	Body	Digital Radio Receiver																																																								
C	2007	Sierra	Body	Driver Door Switch																																																								
C	2007	Sierra	Body	HVAC Control Module Auto																																																								
C	2007	Sierra	Body	HVAC Control Module Manual																																																								
C	2007	Sierra	Body	Instrument Panel Cluster																																																								
C	2007	Sierra	Body	Memory Seat Module																																																								
C	2007	Sierra	Body	Park Assist Module																																																								
C	2007	Sierra	Body	Passenger Door Switch																																																								
C	2007	Sierra	Body	Passenger Presence System																																																								
C	2007	Sierra	Body	Radio																																																								
C	2007	Sierra	Body	Rear Heated Seat Module																																																								
C	2007	Sierra	Body	Rear HVAC/RSA																																																								
C	2007	Sierra	Body	Rollover Sensor																																																								
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																																								
C	2007	Sierra	Body	Theft Deterrent Module																																																								
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																								
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																								
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																								
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																								
C	2007	Yukon	Chassis	Electronic Suspension Control																																																								
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																								
C	2007	Yukon	Body	Amplifier (Bose)																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2007	Yukon	Body	Assist Step Controller																																																									
C	2007	Yukon	Body	Body Control Module																																																									
C	2007	Yukon	Body	Body Control Module (aux.)																																																									
C	2007	Yukon	Body	Digital Radio Receiver																																																									
C	2007	Yukon	Body	Driver Door Switch																																																									
C	2007	Yukon	Body	HVAC Control Module Auto																																																									
C	2007	Yukon	Body	HVAC Control Module Manual																																																									
C	2007	Yukon	Body	Instrument Panel Cluster																																																									
C	2007	Yukon	Body	Lift Gate Module																																																									
C	2007	Yukon	Body	Memory Seat Module																																																									
C	2007	Yukon	Body	Park Assist Module																																																									
C	2007	Yukon	Body	Passenger Door Switch																																																									
C	2007	Yukon	Body	Passenger Presence System																																																									
C	2007	Yukon	Body	Radio																																																									
C	2007	Yukon	Body	Rear Heated Seat Module																																																									
C	2007	Yukon	Body	Rear HVAC/RSA																																																									
C	2007	Yukon	Body	Rollover Sensor																																																									
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																																									
C	2007	Yukon	Body	Theft Deterrent Module																																																									
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																									
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																									
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																									
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																									
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																									
C	2007	Yukon XL	Body	Amplifier (Bose)																																																									
C	2007	Yukon XL	Body	Assist Step Controller																																																									
C	2007	Yukon XL	Body	Body Control Module																																																									
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																									
C	2007	Yukon XL	Body	Digital Radio Receiver																																																									
C	2007	Yukon XL	Body	Driver Door Switch																																																									
C	2007	Yukon XL	Body	HVAC Control Module Auto																																																									
C	2007	Yukon XL	Body	HVAC Control Module Manual																																																									
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																									
C	2007	Yukon XL	Body	Lift Gate Module																																																									
C	2007	Yukon XL	Body	Memory Seat Module																																																									
C	2007	Yukon XL	Body	Park Assist Module																																																									
C	2007	Yukon XL	Body	Passenger Door Switch																																																									
C	2007	Yukon XL	Body	Passenger Presence System																																																									
C	2007	Yukon XL	Body	Radio																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2007	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																											
C	2007	Yukon XL	Body	Rollover Sensor																																																											
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
C	2007	Yukon XL	Body	Theft Deterrent Module																																																											
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V											V				V				
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																															
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2008	Sierra	Chassis	Electronic Suspension Control																																																											
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																											
C	2008	Sierra	Body	Amplifier (Bose)																																																											
C	2008	Sierra	Body	Body Control Module																																																										
C	2008	Sierra	Body	Body Control Module (aux.)																																																										
C	2008	Sierra	Body	Digital Radio Receiver																																																										
C	2008	Sierra	Body	Driver Door Switch																																																										
C	2008	Sierra	Body	HVAC Control Module Auto																																																										
C	2008	Sierra	Body	HVAC Control Module Manual																																																										
C	2008	Sierra	Body	Instrument Panel Cluster																																																										
C	2008	Sierra	Body	Memory Seat Module																																																										
C	2008	Sierra	Body	Park Assist Module																																																										
C	2008	Sierra	Body	Passenger Door Switch																																																										
C	2008	Sierra	Body	Passenger Presence System																																																										
C	2008	Sierra	Body	Radio																																																										
C	2008	Sierra	Body	Rear Heated Seat Module																																																											
C	2008	Sierra	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2008	Sierra	Body	Rollover Sensor																																																										
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2008	Sierra	Body	Theft Deterrent Module																																																										
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Yukon	Chassis	Electronic Brake Control Module																																																										
C	2008	Yukon	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon	Body	Amplifier (Bose)																																																										
C	2008	Yukon	Body	Assist Step Controller																																																										
C	2008	Yukon	Body	Body Control Module																																																										
C	2008	Yukon	Body	Body Control Module (aux.)																																																										
C	2008	Yukon	Body	Digital Radio Receiver																																																										
C	2008	Yukon	Body	Driver Door Switch																																																										
C	2008	Yukon	Body	HVAC Control Module Auto																																																										
C	2008	Yukon	Body	HVAC Control Module Manual																																																										
C	2008	Yukon	Body	Instrument Panel Cluster																																																										
C	2008	Yukon	Body	Lift Gate Module																																																										
C	2008	Yukon	Body	Memory Seat Module																																																										
C	2008	Yukon	Body	Park Assist Module																																																										
C	2008	Yukon	Body	Passenger Door Switch																																																										
C	2008	Yukon	Body	Passenger Presence System																																																										
C	2008	Yukon	Body	Radio																																																										
C	2008	Yukon	Body	Rear Heated Seat Module																																																										
C	2008	Yukon	Body	Rear HVAC/RSA																																																										
C	2008	Yukon	Body	Rollover Sensor																																																										
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																																										
C	2008	Yukon	Body	Theft Deterrent Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																												
C	2008	Yukon Hybrid	Body	Body Control Module																																																												
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																												
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																												
C	2008	Yukon Hybrid	Body	HVAC Control Module																																																												
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
C	2008	Yukon Hybrid	Body	Lift Gate Module																																																												
C	2008	Yukon Hybrid	Body	Memory Seat Module																																																												
C	2008	Yukon Hybrid	Body	Park Assist Module																																																												
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																												
C	2008	Yukon Hybrid	Body	Passenger Presence System																																																												
C	2008	Yukon Hybrid	Body	Radio																																																												
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																												
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon XL	Body	Amplifier (Bose)																																																												
C	2008	Yukon XL	Body	Assist Step Controller																																																												
C	2008	Yukon XL	Body	Body Control Module																																																												
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2008	Yukon XL	Body	Digital Radio Receiver																																																												
C	2008	Yukon XL	Body	Driver Door Switch																																																												
C	2008	Yukon XL	Body	HVAC Control Module Auto																																																												
C	2008	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2008	Yukon XL	Body	Lift Gate Module																																																												
C	2008	Yukon XL	Body	Memory Seat Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2008	Yukon XL	Body	Park Assist Module																																																									
C	2008	Yukon XL	Body	Passenger Door Switch																																																										
C	2008	Yukon XL	Body	Passenger Presence System																																																										
C	2008	Yukon XL	Body	Radio																																																										
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2008	Yukon XL	Body	Rollover Sensor																																																										
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
C	2008	Yukon XL	Body	Theft Deterrent Module																																																										
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V											V			V						
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																															
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual																																																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2009	Sierra	Chassis	Electronic Suspension Control																																																										
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																										
C	2009	Sierra	Body	Amplifier (Bose)																																																										
C	2009	Sierra	Body	Body Control Module																																																										
C	2009	Sierra	Body	Body Control Module (aux.)																																																										
C	2009	Sierra	Body	Digital Radio Receiver																																																										
C	2009	Sierra	Body	Driver Door Switch																																																										
C	2009	Sierra	Body	HVAC Control Module Auto																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2009	Sierra	Body	HVAC Control Module Manual																																																										
C	2009	Sierra	Body	Instrument Panel Cluster																																																											
C	2009	Sierra	Body	Memory Seat Module																																																											
C	2009	Sierra	Body	Park Assist Module																																																											
C	2009	Sierra	Body	Passenger Door Switch																																																											
C	2009	Sierra	Body	Passenger Presence System																																																											
C	2009	Sierra	Body	Radio																																																											
C	2009	Sierra	Body	Rear Heated Seat Module																																																											
C	2009	Sierra	Body	Rear HVAC/RSA																																																											
C	2009	Sierra	Body	Rollover Sensor																																																											
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																																											
C	2009	Sierra	Body	Theft Deterrent Module																																																											
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																											
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																											
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																											
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																											
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																											
C	2009	Sierra Hybrid	Body	Body Control Module																																																											
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																											
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																											
C	2009	Sierra Hybrid	Body	Driver Door Switch																																																											
C	2009	Sierra Hybrid	Body	HVAC Control Module																																																											
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																											
C	2009	Sierra Hybrid	Body	Memory Seat Module																																																											
C	2009	Sierra Hybrid	Body	Park Assist Module																																																											
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																																											
C	2009	Sierra Hybrid	Body	Passenger Presence System																																																											
C	2009	Sierra Hybrid	Body	Radio																																																											
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																											
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																											
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																											
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																											
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																											
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																											
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed																																																											
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed																																																											
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																											
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																											
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
C	2009	Yukon	Chassis	Electronic Brake Control Module																																																													
C	2009	Yukon	Chassis	Electronic Suspension Control																																																													
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																													
C	2009	Yukon	Body	Amplifier (Bose)																																																													
C	2009	Yukon	Body	Assist Step Controller																																																													
C	2009	Yukon	Body	Body Control Module																																																													
C	2009	Yukon	Body	Body Control Module (aux.)																																																													
C	2009	Yukon	Body	Digital Radio Receiver																																																													
C	2009	Yukon	Body	Driver Door Switch																																																													
C	2009	Yukon	Body	HVAC Control Module Auto																																																													
C	2009	Yukon	Body	HVAC Control Module Manual																																																													
C	2009	Yukon	Body	Instrument Panel Cluster																																																													
C	2009	Yukon	Body	Left Side Object Detection Module																																																													
C	2009	Yukon	Body	Lift Gate Module																																																													
C	2009	Yukon	Body	Memory Seat Module																																																													
C	2009	Yukon	Body	Park Assist Module																																																													
C	2009	Yukon	Body	Passenger Door Switch																																																													
C	2009	Yukon	Body	Passenger Presence System																																																													
C	2009	Yukon	Body	Radio																																																													
C	2009	Yukon	Body	Rear Heated Seat Module																																																													
C	2009	Yukon	Body	Rear HVAC/RSA																																																													
C	2009	Yukon	Body	Right Side Object Detection Module																																																													
C	2009	Yukon	Body	Rollover Sensor																																																													
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																																													
C	2009	Yukon	Body	Theft Deterrent Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																													
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																													
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																													
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																													
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																													
C	2009	Yukon Hybrid	Body	Body Control Module																																																													

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2009	Yukon Hybrid	Body	Driver Door Switch																																																										
C	2009	Yukon Hybrid	Body	Heated Seat Module																																																										
C	2009	Yukon Hybrid	Body	HVAC Control Module																																																										
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
C	2009	Yukon Hybrid	Body	Park Assist Module																																																										
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																																										
C	2009	Yukon Hybrid	Body	Passenger Presence System																																																										
C	2009	Yukon Hybrid	Body	Radio																																																										
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																										
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																										
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2009	Yukon XL	Body	Amplifier (Bose)																																																										
C	2009	Yukon XL	Body	Assist Step Controller																																																										
C	2009	Yukon XL	Body	Body Control Module																																																										
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2009	Yukon XL	Body	Digital Radio Receiver																																																										
C	2009	Yukon XL	Body	Driver Door Switch																																																										
C	2009	Yukon XL	Body	HVAC Control Module Auto																																																										
C	2009	Yukon XL	Body	HVAC Control Module Manual																																																										
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2009	Yukon XL	Body	Left Side Object Detection Module																																																										
C	2009	Yukon XL	Body	Lift Gate Module																																																										
C	2009	Yukon XL	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2009	Yukon XL	Body	Park Assist Module																																																										
C	2009	Yukon XL	Body	Passenger Door Switch																																																											
C	2009	Yukon XL	Body	Passenger Presence System																																																											
C	2009	Yukon XL	Body	Radio																																																											
C	2009	Yukon XL	Body	Rear Heated Seat Module																																																											
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																											
C	2009	Yukon XL	Body	Right Side Object Detection Module																																																											
C	2009	Yukon XL	Body	Rollover Sensor																																																											
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
C	2009	Yukon XL	Body	Theft Deterrent Module																																																											
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																											
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V											V			V						
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																															
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																											
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																											
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2010	Sierra	Chassis	Electronic Suspension Control																																																											
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																											
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Sierra	Body	Amplifier (Bose)																																																											
C	2010	Sierra	Body	Body Control Module																																																										
C	2010	Sierra	Body	Body Control Module (aux.)																																																											
C	2010	Sierra	Body	Digital Radio Receiver																																																											
C	2010	Sierra	Body	Driver Door Switch																																																											
C	2010	Sierra	Body	HVAC Control Module Auto																																																											
C	2010	Sierra	Body	HVAC Control Module Manual																																																											
C	2010	Sierra	Body	Instrument Panel Cluster																																																											
C	2010	Sierra	Body	Memory Seat Module																																																											
C	2010	Sierra	Body	Park Assist Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2010	Sierra	Body	Passenger Door Switch																																																												
C	2010	Sierra	Body	Passenger Presence System																																																												
C	2010	Sierra	Body	Radio																																																												
C	2010	Sierra	Body	Rear Heated Seat Module																																																												
C	2010	Sierra	Body	Rear HVAC/RSA																																																												
C	2010	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2010	Sierra	Body	Theft Deterrent Module																																																												
C	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																												
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																												
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																												
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																												
C	2010	Sierra Hybrid	Body	Body Control Module																																																												
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																												
C	2010	Sierra Hybrid	Body	Driver Door Switch																																																												
C	2010	Sierra Hybrid	Body	Heated Seat Module																																																												
C	2010	Sierra Hybrid	Body	HVAC Control Module																																																												
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
C	2010	Sierra Hybrid	Body	Park Assist Module																																																												
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																																												
C	2010	Sierra Hybrid	Body	Passenger Presence System																																																												
C	2010	Sierra Hybrid	Body	Radio																																																												
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																												
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Yukon	Chassis	Electronic Brake Control Module																																																												
C	2010	Yukon	Chassis	Electronic Suspension Control																																																												
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon	Body	Amplifier (Bose)																																																												
C	2010	Yukon	Body	Assist Step Controller																																																												
C	2010	Yukon	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2010	Yukon	Body	Body Control Module (aux.)																																																										
C	2010	Yukon	Body	Digital Radio Receiver																																																											
C	2010	Yukon	Body	Driver Door Switch																																																											
C	2010	Yukon	Body	HVAC Control Module Auto																																																											
C	2010	Yukon	Body	HVAC Control Module Manual																																																												
C	2010	Yukon	Body	Instrument Panel Cluster																																																												
C	2010	Yukon	Body	Left Side Object Detection Module																																																												
C	2010	Yukon	Body	Lift Gate Module																																																												
C	2010	Yukon	Body	Memory Seat Module																																																												
C	2010	Yukon	Body	Park Assist Module																																																												
C	2010	Yukon	Body	Passenger Door Switch																																																												
C	2010	Yukon	Body	Passenger Presence System																																																												
C	2010	Yukon	Body	Radio																																																												
C	2010	Yukon	Body	Rear Heated Seat Module																																																												
C	2010	Yukon	Body	Rear HVAC/RSA																																																												
C	2010	Yukon	Body	Right Side Object Detection Module																																																												
C	2010	Yukon	Body	Supplemental Inflatable Restraint																																																												
C	2010	Yukon	Body	Theft Deterrent Module																																																												
C	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																												
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																												
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																												
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																												
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																												
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																												
C	2010	Yukon Hybrid	Body	Body Control Module																																																												
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																												
C	2010	Yukon Hybrid	Body	Driver Door Switch																																																												
C	2010	Yukon Hybrid	Body	Heated Seat Module																																																												
C	2010	Yukon Hybrid	Body	HVAC Control Module																																																												
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
C	2010	Yukon Hybrid	Body	Lift Gate Module																																																												
C	2010	Yukon Hybrid	Body	Park Assist Module																																																												
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																																												
C	2010	Yukon Hybrid	Body	Passenger Presence System																																																												
C	2010	Yukon Hybrid	Body	Radio																																																												
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																										
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																												
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																												
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2010	Yukon XL	Body	Amplifier (Bose)																																																												
C	2010	Yukon XL	Body	Assist Step Controller																																																												
C	2010	Yukon XL	Body	Body Control Module																																																												
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2010	Yukon XL	Body	Digital Radio Receiver																																																												
C	2010	Yukon XL	Body	Driver Door Switch																																																												
C	2010	Yukon XL	Body	HVAC Control Module Auto																																																												
C	2010	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2010	Yukon XL	Body	Left Side Object Detection Module																																																												
C	2010	Yukon XL	Body	Lift Gate Module																																																												
C	2010	Yukon XL	Body	Memory Seat Module																																																												
C	2010	Yukon XL	Body	Park Assist Module																																																												
C	2010	Yukon XL	Body	Passenger Door Switch																																																												
C	2010	Yukon XL	Body	Passenger Presence System																																																												
C	2010	Yukon XL	Body	Radio																																																												
C	2010	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2010	Yukon XL	Body	Right Side Object Detection Module																																																												
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2010	Yukon XL	Body	Theft Deterrent Module																																																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																												
D	2008	ALL	Chassis	Electronic Brake Control Module																																																												
D	2008	ALL	Body	Body Control Module																																																											
D	2008	ALL	Body	Body Control Module (aux.)																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
D	2008	ALL	Body	Headlamp Control Module																																																										
D	2008	ALL	Body	HVAC Control Module Auto																																																										
D	2008	ALL	Body	Instrument Panel Cluster																																																										
D	2008	ALL	Body	Park Assist Module																																																										
D	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
D	2008	ALL	Body	Theft Deterrent Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2009	ALL	Chassis	Electronic Brake Control Module																																																										
D	2009	ALL	Body	Body Control Module																																																										
D	2009	ALL	Body	Body Control Module (aux.)																																																										
D	2009	ALL	Body	Headlamp Control Module																																																										
D	2009	ALL	Body	HVAC Control Module Auto																																																										
D	2009	ALL	Body	Instrument Panel Cluster																																																										
D	2009	ALL	Body	Park Assist Module																																																										
D	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
D	2009	ALL	Body	Theft Deterrent Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2010	ALL	Chassis	Electronic Brake Control Module																																																										
D	2010	ALL	Body	Body Control Module																																																										
D	2010	ALL	Body	Body Control Module (aux.)																																																										
D	2010	ALL	Body	Headlamp Control Module																																																										
D	2010	ALL	Body	HVAC Control Module Auto																																																										
D	2010	ALL	Body	Instrument Panel Cluster																																																										
D	2010	ALL	Body	Park Assist Module																																																										
D	2010	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																										
G	2004	Express/Savana	Body	Body Control Module																																																										
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2004	Express/Savana	Body	OnStar																																																										
G	2004	Express/Savana	Body	Base Radio																																																										
G	2004	Express/Savana	Body	Uplevel Radio																																																										
G	2004	Express/Savana	Body	Remote Function Actuation																																																										
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																																										
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2005	Express/Savana	Chassis	VSES																																																										
G	2005	Express/Savana	Body	Body Control Module																																																										
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2005	Express/Savana	Body	Base Radio																																																										
G	2005	Express/Savana	Body	Uplevel Radio																																																										
G	2005	Express/Savana	Body	Remote Function Actuation																																																										
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2005	Express Access/Savana Pro	Chassis	VSES																																																										
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2005	Express Access/Savana Pro	Body	Base Radio																																																										
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																						V			
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																								
G	2006	Express/Savana	Chassis	VSES																																																								
G	2006	Express/Savana	Body	Body Control Module																																																								
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2006	Express/Savana	Body	Passenger Presence System																																																								
G	2006	Express/Savana	Body	Base Radio																																																								
G	2006	Express/Savana	Body	Uplevel Radio																																																								
G	2006	Express/Savana	Body	Remote Function Actuation																																																								
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																					V			
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
G	2006	Express Access/Savana Pro	Chassis	VSES																																																								
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2006	Express Access/Savana Pro	Body	Base Radio																																																								
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																								
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																							V		
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																												V																												
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2007	Express/Savana	Body	Body Control Module																																																								
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2007	Express/Savana	Body	Passenger Presence System																																																								
G	2007	Express/Savana	Body	Base Radio																																																								
G	2007	Express/Savana	Body	Uplevel Radio																																																								
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																							V		
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																							
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																							
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																											V																													
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																							
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																							
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																							
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																							
G	2007	Express Access/Savana Pro	Body	Radio																																																							
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																							
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																							
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																							
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																							
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																							
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																							
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																							
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																							
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																							
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																										V										V											V			V			
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																												V																												
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																							
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																							
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																							
G	2008	Express/Savana	Body	Body Control Module																																																							
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																							
G	2008	Express/Savana	Body	Passenger Presence System																																																							
G	2008	Express/Savana	Body	Radio																																																							
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
G	2008	Express/Savana	Body	Rollover Sensor																																																							
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																							
G	2008	Express/Savana	Body	Theft Deterrent Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																							
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																										V										V											V			V			
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																												V																												
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																							
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																							

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2008	Express Access/Savana Pro	Body	Radio																																																										
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V											V				V				
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																														
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2009	Express/Savana	Body	Body Control Module																																																										
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2009	Express/Savana	Body	Passenger Presence System																																																										
G	2009	Express/Savana	Body	Radio																																																										
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express/Savana	Body	Rollover Sensor																																																										
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2009	Express/Savana	Body	Theft Deterrent Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V											V				V				
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																														
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2009	Express Access/Savana Pro	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																		V							V		V										V	V			V	V		V
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																											V																															
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V										V										V			V				
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																															
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2010	Express/Savana	Body	Body Control Module																																																										
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2010	Express/Savana	Body	Passenger Presence System																																																										
G	2010	Express/Savana	Body	Radio																																																									
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2010	Express/Savana	Body	Rollover Sensor																																																										
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2010	Express/Savana	Body	Theft Deterrent Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																		V							V		V										V	V			V	V		V
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																											V																															
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V										V										V							
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																															
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2010	Express Access/Savana Pro	Body	Radio																																																										
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2004	Express/Savana	Chassis	VSES																																																										
H	2004	Express/Savana	Body	Body Control Module																																																										
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2004	Express/Savana	Body	OnStar																																																										
H	2004	Express/Savana	Body	Base Radio																																																										
H	2004	Express/Savana	Body	Uplevel Radio																																																										
H	2004	Express/Savana	Body	Remote Function Actuation																																																										
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2004	Express Access/Savana Pro	Chassis	VSES																																																										
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2004	Express Access/Savana Pro	Body	OnStar																																																										
H	2004	Express Access/Savana Pro	Body	Base Radio																																																										
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2005	Express/Savana	Chassis	VSES																																																										
H	2005	Express/Savana	Body	Body Control Module																																																										
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2005	Express/Savana	Body	Base Radio																																																										
H	2005	Express/Savana	Body	Uplevel Radio																																																										
H	2005	Express/Savana	Body	Remote Function Actuation																																																										
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2005	Express Access/Savana Pro	Chassis	VSES																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2005	Express Access/Savana Pro	Body	Base Radio																																																										
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2006	Express/Savana	Chassis	VSES																																																										
H	2006	Express/Savana	Body	Body Control Module																																																										
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2006	Express/Savana	Body	Passenger Presence System																																																										
H	2006	Express/Savana	Body	Base Radio																																																										
H	2006	Express/Savana	Body	Uplevel Radio																																																										
H	2006	Express/Savana	Body	Remote Function Actuation																																																										
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2006	Express Access/Savana Pro	Chassis	VSES																																																										
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2006	Express Access/Savana Pro	Body	Base Radio																																																										
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express/Savana	Body	Body Control Module																																																										
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2007	Express/Savana	Body	Passenger Presence System																																																										
H	2007	Express/Savana	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2007	Express/Savana	Body	Uplevel Radio																																																									
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2007	Express Access/Savana Pro	Body	Base Radio																																																										
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express/Savana	Body	Body Control Module																																																										
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2008	Express/Savana	Body	Passenger Presence System																																																										
H	2008	Express/Savana	Body	Radio																																																										
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express/Savana	Body	Rollover Sensor																																																										
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express/Savana	Body	Theft Deterrent Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module																																																										
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																																										
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express/Savana	Body	Theft Deterrent Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express/Savana	Body	Body Control Module																																																										
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2010	Express/Savana	Body	Passenger Presence System																																																										
H	2010	Express/Savana	Body	Radio																																																										
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express/Savana	Body	Rollover Sensor																																																										
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express/Savana	Body	Theft Deterrent Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2010	Express Access/Savana Pro	Body	Radio																																																										
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																										
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2004	ALL	Chassis	ESC																																																									
K	2004	ALL	Chassis	Rear Wheel Steering																																																										
K	2004	ALL	Chassis	Tire Pressure Monitor																																																										
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2004	ALL	Chassis	VSES																																																									
K	2004	ALL	Body	Amplifier (Bose)																																																										
K	2004	ALL	Body	Body Control Module																																																										
K	2004	ALL	Body	CD Changer																																																										
K	2004	ALL	Body	Chime																																																										
K	2004	ALL	Body	Driver Door Module																																																										
K	2004	ALL	Body	Driver Seat Module																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2004	ALL	Body	Instrument Panel Cluster																																																										
K	2004	ALL	Body	OnStar																																																									
K	2004	ALL	Body	Passenger Door Module																																																										
K	2004	ALL	Body	Passenger Presence System																																																										
K	2004	ALL	Body	Radio Base																																																										
K	2004	ALL	Body	Radio Uplevel																																																										
K	2004	ALL	Body	Radio Navigation																																																										
K	2004	ALL	Body	Rear Aux. Climate Module																																																										
K	2004	ALL	Body	Rear HVAC																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2004	ALL	Body	Rear Seat Audio																																																									
K	2004	ALL	Body	Rear Seat Entertainment																																																									
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2004	ALL	Body	Vehicle Theft Deterrent																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																						V			
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																									
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
K	2005	ALL	Chassis	ESC																																																									
K	2005	ALL	Chassis	Rear Wheel Steering																																																									
K	2005	ALL	Chassis	Tire Pressure Monitor																																																									
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																									
K	2005	ALL	Chassis	VSES																																																									
K	2005	ALL	Body	Amplifier (Bose)																																																									
K	2005	ALL	Body	Body Control Module																																																									
K	2005	ALL	Body	CD Changer																																																									
K	2005	ALL	Body	Chime																																																									
K	2005	ALL	Body	Disc Player and Video Display																																																									
K	2005	ALL	Body	Driver Door Module																																																									
K	2005	ALL	Body	Driver Seat Module																																																									
K	2005	ALL	Body	Generator Battery Control Module																																																									
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																									
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																									
K	2005	ALL	Body	Instrument Panel Cluster																																																									
K	2005	ALL	Body	Passenger Door Module																																																									
K	2005	ALL	Body	Passenger Presence System																																																									
K	2005	ALL	Body	Base Radio																																																									
K	2005	ALL	Body	Uplevel Radio																																																									
K	2005	ALL	Body	Navigation Radio																																																									
K	2005	ALL	Body	Rear Aux. Climate Module																																																									
K	2005	ALL	Body	Rear HVAC																																																									
K	2005	ALL	Body	Rear Seat Audio																																																									
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																									
K	2005	ALL	Body	Vehicle Theft Deterrent																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																						V			
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																					V			
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																									
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																									
K	2006	ALL	Chassis	ESC																																																								
K	2006	ALL	Chassis	Tire Pressure Monitor																																																									
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																									
K	2006	ALL	Chassis	VSES																																																								
K	2006	ALL	Body	Amplifier (Bose)																																																								
K	2006	ALL	Body	Body Control Module																																																								
K	2006	ALL	Body	CD Changer																																																								
K	2006	ALL	Body	Chime																																																								
K	2006	ALL	Body	Disc Player and Video Display																																																								
K	2006	ALL	Body	Driver Door Module																																																								
K	2006	ALL	Body	Driver Seat Module																																																								
K	2006	ALL	Body	Generator Battery Control Module																																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2006	ALL	Body	Instrument Panel Cluster																																																										
K	2006	ALL	Body	Passenger Door Module																																																										
K	2006	ALL	Body	Passenger Presence System																																																										
K	2006	ALL	Body	Base Radio																																																										
K	2006	ALL	Body	Uplevel Radio																																																										
K	2006	ALL	Body	Navigation Radio																																																										
K	2006	ALL	Body	Rear Aux. Climate Module																																																										
K	2006	ALL	Body	Rear HVAC																																																										
K	2006	ALL	Body	Rear Seat Audio																																																										
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2006	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V											V			V						
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																														
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Sierra	Chassis	Electronic Suspension Control																																																										
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2007	Sierra	Body	Amplifier (Bose)																																																										
K	2007	Sierra	Body	Body Control Module																																																										
K	2007	Sierra	Body	Body Control Module (aux.)																																																										
K	2007	Sierra	Body	Digital Radio Receiver																																																										
K	2007	Sierra	Body	Driver Door Switch																																																										
K	2007	Sierra	Body	HVAC Control Module Auto																																																										
K	2007	Sierra	Body	HVAC Control Module Manual																																																										
K	2007	Sierra	Body	Instrument Panel Cluster																																																										
K	2007	Sierra	Body	Memory Seat Module																																																										
K	2007	Sierra	Body	Park Assist Module																																																										
K	2007	Sierra	Body	Passenger Door Switch																																																										
K	2007	Sierra	Body	Passenger Presence System																																																										
K	2007	Sierra	Body	Radio																																																										
K	2007	Sierra	Body	Rear Heated Seat Module																																																										
K	2007	Sierra	Body	Rear HVAC/RSA																																																										
K	2007	Sierra	Body	Rollover Sensor																																																										
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2007	Sierra	Body	Theft Deterrent Module																																																										
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Yukon	Chassis	Electronic Suspension Control																																																										
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																										
K	2007	Yukon	Body	Amplifier (Bose)																																																										
K	2007	Yukon	Body	Assist Step Controller																																																										
K	2007	Yukon	Body	Body Control Module																																																										
K	2007	Yukon	Body	Body Control Module (aux.)																																																										
K	2007	Yukon	Body	Digital Radio Receiver																																																										
K	2007	Yukon	Body	Driver Door Switch																																																										
K	2007	Yukon	Body	HVAC Control Module Auto																																																										
K	2007	Yukon	Body	HVAC Control Module Manual																																																										
K	2007	Yukon	Body	Instrument Panel Cluster																																																										
K	2007	Yukon	Body	Lift Gate Module																																																										
K	2007	Yukon	Body	Memory Seat Module																																																										
K	2007	Yukon	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2007	Yukon	Body	Passenger Door Switch																																																											
K	2007	Yukon	Body	Passenger Presence System																																																											
K	2007	Yukon	Body	Radio																																																											
K	2007	Yukon	Body	Rear Heated Seat Module																																																											
K	2007	Yukon	Body	Rear HVAC/RSA																																																											
K	2007	Yukon	Body	Rollover Sensor																																																											
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																																											
K	2007	Yukon	Body	Theft Deterrent Module																																																											
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																											
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																											
K	2007	Yukon XL	Body	Amplifier (Bose)																																																											
K	2007	Yukon XL	Body	Assist Step Controller																																																											
K	2007	Yukon XL	Body	Body Control Module																																																											
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																											
K	2007	Yukon XL	Body	Digital Radio Receiver																																																											
K	2007	Yukon XL	Body	Driver Door Switch																																																											
K	2007	Yukon XL	Body	HVAC Control Module Auto																																																											
K	2007	Yukon XL	Body	HVAC Control Module Manual																																																											
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																											
K	2007	Yukon XL	Body	Lift Gate Module																																																											
K	2007	Yukon XL	Body	Memory Seat Module																																																											
K	2007	Yukon XL	Body	Park Assist Module																																																											
K	2007	Yukon XL	Body	Passenger Door Switch																																																											
K	2007	Yukon XL	Body	Passenger Presence System																																																											
K	2007	Yukon XL	Body	Radio																																																										
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																											
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																											
K	2007	Yukon XL	Body	Rollover Sensor																																																											
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
K	2007	Yukon XL	Body	Theft Deterrent Module																																																											
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V									V			V							
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																															
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Sierra	Chassis	Electronic Suspension Control																																																										
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2008	Sierra	Body	Amplifier (Bose)																																																										
K	2008	Sierra	Body	Body Control Module																																																									
K	2008	Sierra	Body	Body Control Module (aux.)																																																									
K	2008	Sierra	Body	Digital Radio Receiver																																																									
K	2008	Sierra	Body	Driver Door Switch																																																									
K	2008	Sierra	Body	HVAC Control Module Auto																																																									
K	2008	Sierra	Body	HVAC Control Module Manual																																																									
K	2008	Sierra	Body	Instrument Panel Cluster																																																									
K	2008	Sierra	Body	Memory Seat Module																																																									
K	2008	Sierra	Body	Park Assist Module																																																									
K	2008	Sierra	Body	Passenger Door Switch																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2008	Sierra	Body	Passenger Presence System																																																									
K	2008	Sierra	Body	Radio																																																									
K	2008	Sierra	Body	Rear Heated Seat Module																																																									
K	2008	Sierra	Body	Rear HVAC/RSA																																																									
K	2008	Sierra	Body	Rollover Sensor																																																									
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																																									
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																									
K	2008	Sierra	Body	Theft Deterrent Module																																																									
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																									
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																									
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																									
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																									
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2008	Yukon	Chassis	Electronic Brake Control Module																																																									
K	2008	Yukon	Chassis	Electronic Suspension Control																																																									
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																									
K	2008	Yukon	Body	Amplifier (Bose)																																																									
K	2008	Yukon	Body	Assist Step Controller																																																									
K	2008	Yukon	Body	Body Control Module																																																									
K	2008	Yukon	Body	Body Control Module (aux.)																																																									
K	2008	Yukon	Body	Digital Radio Receiver																																																									
K	2008	Yukon	Body	Driver Door Switch																																																									
K	2008	Yukon	Body	HVAC Control Module Auto																																																									
K	2008	Yukon	Body	HVAC Control Module Manual																																																									
K	2008	Yukon	Body	Instrument Panel Cluster																																																									
K	2008	Yukon	Body	Lift Gate Module																																																									
K	2008	Yukon	Body	Memory Seat Module																																																									
K	2008	Yukon	Body	Park Assist Module																																																									
K	2008	Yukon	Body	Passenger Door Switch																																																									
K	2008	Yukon	Body	Passenger Presence System																																																									
K	2008	Yukon	Body	Radio																																																									
K	2008	Yukon	Body	Rear Heated Seat Module																																																									
K	2008	Yukon	Body	Rear HVAC/RSA																																																									
K	2008	Yukon	Body	Rollover Sensor																																																									
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																																									
K	2008	Yukon	Body	Theft Deterrent Module																																																									
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																									
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																											
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																											
K	2008	Yukon Hybrid	Body	Body Control Module																																																											
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																											
K	2008	Yukon Hybrid	Body	Driver Door Switch																																																											
K	2008	Yukon Hybrid	Body	HVAC Control Module																																																											
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
K	2008	Yukon Hybrid	Body	Lift Gate Module																																																											
K	2008	Yukon Hybrid	Body	Memory Seat Module																																																											
K	2008	Yukon Hybrid	Body	Park Assist Module																																																											
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																																											
K	2008	Yukon Hybrid	Body	Passenger Presence System																																																											
K	2008	Yukon Hybrid	Body	Radio																																																											
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																											
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																									
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2008	Yukon XL	Body	Amplifier (Bose)																																																										
K	2008	Yukon XL	Body	Assist Step Controller																																																										
K	2008	Yukon XL	Body	Body Control Module																																																										
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2008	Yukon XL	Body	Digital Radio Receiver																																																										
K	2008	Yukon XL	Body	Driver Door Switch																																																										
K	2008	Yukon XL	Body	HVAC Control Module Auto																																																										
K	2008	Yukon XL	Body	HVAC Control Module Manual																																																										
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2008	Yukon XL	Body	Lift Gate Module																																																										
K	2008	Yukon XL	Body	Memory Seat Module																																																										
K	2008	Yukon XL	Body	Park Assist Module																																																										
K	2008	Yukon XL	Body	Passenger Door Switch																																																										
K	2008	Yukon XL	Body	Passenger Presence System																																																										
K	2008	Yukon XL	Body	Radio																																																										
K	2008	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2008	Yukon XL	Body	Rollover Sensor																																																										
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2008	Yukon XL	Body	Theft Deterrent Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V										V										V				V			
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																														
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2009	Sierra	Chassis	Electronic Suspension Control																																																												
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																												
K	2009	Sierra	Body	Amplifier (Bose)																																																												
K	2009	Sierra	Body	Body Control Module																																																											
K	2009	Sierra	Body	Body Control Module (aux.)																																																											
K	2009	Sierra	Body	Digital Radio Receiver																																																											
K	2009	Sierra	Body	Driver Door Switch																																																											
K	2009	Sierra	Body	HVAC Control Module Auto																																																											
K	2009	Sierra	Body	HVAC Control Module Manual																																																											
K	2009	Sierra	Body	Instrument Panel Cluster																																																											
K	2009	Sierra	Body	Memory Seat Module																																																											
K	2009	Sierra	Body	Park Assist Module																																																											
K	2009	Sierra	Body	Passenger Door Switch																																																											
K	2009	Sierra	Body	Passenger Presence System																																																											
K	2009	Sierra	Body	Radio																																																											
K	2009	Sierra	Body	Rear Heated Seat Module																																																											
K	2009	Sierra	Body	Rear HVAC/RSA																																																											
K	2009	Sierra	Body	Rollover Sensor																																																											
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																																											
K	2009	Sierra	Body	Theft Deterrent Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																											
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																												
K	2009	Sierra Hybrid	Body	Body Control Module																																																												
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Sierra Hybrid	Body	Driver Door Switch																																																												
K	2009	Sierra Hybrid	Body	HVAC Control Module																																																												
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
K	2009	Sierra Hybrid	Body	Memory Seat Module																																																												
K	2009	Sierra Hybrid	Body	Park Assist Module																																																												
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																																												
K	2009	Sierra Hybrid	Body	Passenger Presence System																																																												
K	2009	Sierra Hybrid	Body	Radio																																																												
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Sierra Hybrid	Body	Rollover Sensor																																																												
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Yukon	Chassis	Electronic Brake Control Module																																																												
K	2009	Yukon	Chassis	Electronic Suspension Control																																																												
K	2009	Yukon	Chassis	Trailer Brake Control Module																																																												
K	2009	Yukon	Body	Amplifier (Bose)																																																												
K	2009	Yukon	Body	Assist Step Controller																																																												
K	2009	Yukon	Body	Body Control Module																																																												
K	2009	Yukon	Body	Body Control Module (aux.)																																																												
K	2009	Yukon	Body	Digital Radio Receiver																																																												
K	2009	Yukon	Body	Driver Door Switch																																																												
K	2009	Yukon	Body	HVAC Control Module Auto																																																												
K	2009	Yukon	Body	HVAC Control Module Manual																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2009	Yukon	Body	Instrument Panel Cluster																																																									
K	2009	Yukon	Body	Left Side Object Detection Module																																																									
K	2009	Yukon	Body	Lift Gate Module																																																									
K	2009	Yukon	Body	Memory Seat Module																																																									
K	2009	Yukon	Body	Park Assist Module																																																									
K	2009	Yukon	Body	Passenger Door Switch																																																									
K	2009	Yukon	Body	Passenger Presence System																																																									
K	2009	Yukon	Body	Radio																																																									
K	2009	Yukon	Body	Rear Heated Seat Module																																																									
K	2009	Yukon	Body	Rear HVAC/RSA																																																									
K	2009	Yukon	Body	Right Side Object Detection Module																																																									
K	2009	Yukon	Body	Rollover Sensor																																																									
K	2009	Yukon	Body	Supplemental Inflatable Restraint																																																									
K	2009	Yukon	Body	Theft Deterrent Module																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																									
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																									
K	2009	Yukon Hybrid	Body	Body Control Module																																																									
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																									
K	2009	Yukon Hybrid	Body	Driver Door Switch																																																									
K	2009	Yukon Hybrid	Body	Heated Seat Module																																																									
K	2009	Yukon Hybrid	Body	HVAC Control Module																																																									
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																									
K	2009	Yukon Hybrid	Body	Park Assist Module																																																									
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																																									
K	2009	Yukon Hybrid	Body	Passenger Presence System																																																									
K	2009	Yukon Hybrid	Body	Radio																																																									
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
K	2009	Yukon Hybrid	Body	Rollover Sensor																																																									
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																									
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																									
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																													
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																													
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																													
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																													
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																													
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																													
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																													
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																													
K	2009	Yukon XL	Body	Amplifier (Bose)																																																													
K	2009	Yukon XL	Body	Assist Step Controller																																																													
K	2009	Yukon XL	Body	Body Control Module																																																													
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																													
K	2009	Yukon XL	Body	Digital Radio Receiver																																																													
K	2009	Yukon XL	Body	Driver Door Switch																																																													
K	2009	Yukon XL	Body	HVAC Control Module Auto																																																													
K	2009	Yukon XL	Body	HVAC Control Module Manual																																																													
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																													
K	2009	Yukon XL	Body	Left Side Object Detection Module																																																													
K	2009	Yukon XL	Body	Lift Gate Module																																																													
K	2009	Yukon XL	Body	Memory Seat Module																																																													
K	2009	Yukon XL	Body	Park Assist Module																																																													
K	2009	Yukon XL	Body	Passenger Door Switch																																																													
K	2009	Yukon XL	Body	Passenger Presence System																																																													
K	2009	Yukon XL	Body	Radio																																																													
K	2009	Yukon XL	Body	Rear Heated Seat Module																																																													
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																													
K	2009	Yukon XL	Body	Right Side Object Detection Module																																																													
K	2009	Yukon XL	Body	Rollover Sensor																																																													
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																													
K	2009	Yukon XL	Body	Theft Deterrent Module																																																													
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																													
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																													
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																													

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module	V																									V									V											V			V					
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																											V																														
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2010	Sierra	Chassis	Electronic Suspension Control																																																										
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra	Body	Amplifier (Bose)																																																										
K	2010	Sierra	Body	Body Control Module																																																									
K	2010	Sierra	Body	Body Control Module (aux.)																																																										
K	2010	Sierra	Body	Digital Radio Receiver																																																										
K	2010	Sierra	Body	Driver Door Switch																																																										
K	2010	Sierra	Body	HVAC Control Module Auto																																																										
K	2010	Sierra	Body	HVAC Control Module Manual																																																										
K	2010	Sierra	Body	Instrument Panel Cluster																																																										
K	2010	Sierra	Body	Memory Seat Module																																																										
K	2010	Sierra	Body	Park Assist Module																																																										
K	2010	Sierra	Body	Passenger Door Switch																																																										
K	2010	Sierra	Body	Passenger Presence System																																																										
K	2010	Sierra	Body	Radio																																																										
K	2010	Sierra	Body	Rear Heated Seat Module																																																										
K	2010	Sierra	Body	Rear HVAC/RSA																																																										
K	2010	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2010	Sierra	Body	Theft Deterrent Module																																																										
K	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Sierra Hybrid	Body	Body Control Module																																																										
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Sierra Hybrid	Body	Driver Door Switch																																																										
K	2010	Sierra Hybrid	Body	Heated Seat Module																																																										
K	2010	Sierra Hybrid	Body	HVAC Control Module																																																										
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Sierra Hybrid	Body	Park Assist Module																																																										
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																																										
K	2010	Sierra Hybrid	Body	Passenger Presence System																																																										
K	2010	Sierra Hybrid	Body	Radio																																																										
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon	Chassis	Electronic Brake Control Module																																																										
K	2010	Yukon	Chassis	Electronic Suspension Control																																																										
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon	Body	Amplifier (Bose)																																																										
K	2010	Yukon	Body	Assist Step Controller																																																										
K	2010	Yukon	Body	Body Control Module																																																										
K	2010	Yukon	Body	Body Control Module (aux.)																																																										
K	2010	Yukon	Body	Digital Radio Receiver																																																										
K	2010	Yukon	Body	Driver Door Switch																																																										
K	2010	Yukon	Body	HVAC Control Module Auto																																																										
K	2010	Yukon	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2010	Yukon	Body	Instrument Panel Cluster																																																										
K	2010	Yukon	Body	Left Side Object Detection Module																																																											
K	2010	Yukon	Body	Lift Gate Module																																																											
K	2010	Yukon	Body	Memory Seat Module																																																											
K	2010	Yukon	Body	Park Assist Module																																																											
K	2010	Yukon	Body	Passenger Door Switch																																																											
K	2010	Yukon	Body	Passenger Presence System																																																											
K	2010	Yukon	Body	Radio																																																											
K	2010	Yukon	Body	Rear Heated Seat Module																																																											
K	2010	Yukon	Body	Rear HVAC/RSA																																																											
K	2010	Yukon	Body	Right Side Object Detection Module																																																											
K	2010	Yukon	Body	Supplemental Inflatable Restraint																																																											
K	2010	Yukon	Body	Theft Deterrent Module																																																											
K	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																											
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																											
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																											
K	2010	Yukon Hybrid	Body	Body Control Module																																																											
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																											
K	2010	Yukon Hybrid	Body	Driver Door Switch																																																											
K	2010	Yukon Hybrid	Body	Heated Seat Module																																																											
K	2010	Yukon Hybrid	Body	HVAC Control Module																																																											
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
K	2010	Yukon Hybrid	Body	Lift Gate Module																																																											
K	2010	Yukon Hybrid	Body	Park Assist Module																																																											
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																																											
K	2010	Yukon Hybrid	Body	Passenger Presence System																																																											
K	2010	Yukon Hybrid	Body	Radio																																																											
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																											
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																											
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																										
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																										
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2010	Yukon XL	Body	Amplifier (Bose)																																																										
K	2010	Yukon XL	Body	Assist Step Controller																																																										
K	2010	Yukon XL	Body	Body Control Module																																																										
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2010	Yukon XL	Body	Digital Radio Receiver																																																										
K	2010	Yukon XL	Body	Driver Door Switch																																																										
K	2010	Yukon XL	Body	HVAC Control Module Auto																																																										
K	2010	Yukon XL	Body	HVAC Control Module Manual																																																										
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2010	Yukon XL	Body	Left Side Object Detection Module																																																										
K	2010	Yukon XL	Body	Lift Gate Module																																																										
K	2010	Yukon XL	Body	Memory Seat Module																																																										
K	2010	Yukon XL	Body	Park Assist Module																																																										
K	2010	Yukon XL	Body	Passenger Door Switch																																																										
K	2010	Yukon XL	Body	Passenger Presence System																																																										
K	2010	Yukon XL	Body	Radio																																																										
K	2010	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2010	Yukon XL	Body	Right Side Object Detection Module																																																										
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2010	Yukon XL	Body	Theft Deterrent Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2004	ALL	Chassis	4WAL 3 Sensor																																																										
L	2004	ALL	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2004	ALL	Body	Instrument Panel Cluster																																																									
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2005	ALL	Chassis	4WAL 3 Sensor																																																										
L	2005	ALL	Body	Body Control Module																																																									
L	2005	ALL	Body	Instrument Panel Cluster																																																										
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																										
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																										
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																										
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2010	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2010	Terrain	Body	Body Control Module																																																										
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2010	Terrain	Body	Passenger Presence Module																																																										
L	2010	Terrain	Body	Instrument Cluster																																																										
L	2010	Terrain	Body	Radio																																																										
L	2010	Terrain	Body	Multimedia Player Interface Module																																																										
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																																										
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2010	Terrain	Body	Liftgate Control Module																																																										
L	2010	Terrain	Body	Parking Assist Control Module																																																										
L	2010	Terrain	Body	Frontview Camera Module																																																										
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																																										
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																																										
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																										
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																										
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2011	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2011	Terrain	Body	Body Control Module																																																										
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2011	Terrain	Body	Passenger Presence Module																																																										
L	2011	Terrain	Body	Instrument Cluster																																																										
L	2011	Terrain	Body	Radio																																																										
L	2011	Terrain	Body	Multimedia Player Interface Module																																																										
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																																									
L	2011	Terrain	Body	Liftgate Control Module																																																										
L	2011	Terrain	Body	Parking Assist Control Module																																																										
L	2011	Terrain	Body	Frontview Camera Module																																																										
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																																										
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																										
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2012	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2012	Terrain	Body	Body Control Module																																																										
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2012	Terrain	Body	Passenger Presence Module																																																										
L	2012	Terrain	Body	Instrument Cluster																																																										
L	2012	Terrain	Body	Radio																																																										
L	2012	Terrain	Body	Multimedia Player Interface Module																																																										
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2012	Terrain	Body	Liftgate Control Module																																																										
L	2012	Terrain	Body	Parking Assist Control Module																																																										
L	2012	Terrain	Body	Frontview Camera Module																																																										
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																																										
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2013	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2013	Terrain	Chassis	Power Steering Control Module																																																										
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																																										
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2013	Terrain	Body	Passenger Presence Module																																																										
L	2013	Terrain	Body	Instrument Cluster																																																										
L	2013	Terrain	Body	Radio																																																										
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2013	Terrain	Body	Liftgate Control Module																																																										
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																										
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																										
L	2013	Terrain	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2013	Terrain	Body	Frontview Camera Module																																																										
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2014	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2014	Terrain	Chassis	Power Steering Control Module																																																										
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																																										
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2014	Terrain	Body	Passenger Presence Module																																																										
L	2014	Terrain	Body	Instrument Cluster																																																										
L	2014	Terrain	Body	Radio																																																										
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2014	Terrain	Body	Liftgate Control Module																																																										
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																										
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																										
L	2014	Terrain	Body	Parking Assist Control Module																																																										
L	2014	Terrain	Body	Frontview Camera Module																																																										
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2015	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2015	Terrain	Chassis	Power Steering Control Module																																																										
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																																										
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2015	Terrain	Body	Passenger Presence Module																																																										
L	2015	Terrain	Body	Instrument Cluster																																																										
L	2015	Terrain	Body	Radio																																																										
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																																										
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2015	Terrain	Body	Liftgate Control Module																																																										
L	2015	Terrain	Body	Seat Memory Control Module																																																										
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																										
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																										
L	2015	Terrain	Body	Parking Assist Control Module																																																										
L	2015	Terrain	Body	Frontview Camera Module																																																										
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2016	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2016	Terrain	Chassis	Power Steering Control Module																																																											
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																																											
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2016	Terrain	Body	Passenger Presence Module																																																											
L	2016	Terrain	Body	Instrument Cluster																																																											
L	2016	Terrain	Body	Radio																																																											
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																																											
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2016	Terrain	Body	Liftgate Control Module																																																											
L	2016	Terrain	Body	Seat Memory Control Module																																																											
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2016	Terrain	Body	Parking Assist Control Module																																																											
L	2016	Terrain	Body	Frontview Camera Module																																																											
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
M	2004	ALL	Chassis	4WAL 3 Sensor																																																											
M	2004	ALL	Body	Body Control Module																																																										
M	2004	ALL	Body	Instrument Panel Cluster																																																										
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
M	2005	ALL	Chassis	4WAL 3 Sensor																																																										
M	2005	ALL	Body	Body Control Module																																																									
M	2005	ALL	Body	Instrument Panel Cluster																																																									
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																									
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																									
P	2007	ALL	Body	Theft Deterrent Module																																																									
R	2007	ALL	Powertrain	Engine Control Module																																																									
R	2007	ALL	Powertrain	Transmission Control Module																																																									
R	2007	ALL	Chassis	Electronic Brake Control Module																																																									
R	2007	ALL	Body	Body Control Module																																																								
R	2007	ALL	Body	Digital Radio Receiver																																																								
R	2007	ALL	Body	Driver Door Switch																																																							
R	2007	ALL	Body	Head Up Display																																																							
R	2007	ALL	Body	Heated Seat Module																																																							
R	2007	ALL	Body	HVAC Control Module Auto																																																							
R	2007	ALL	Body	HVAC Control Module Manual																																																							
R	2007	ALL	Body	Instrument Panel Cluster																																																						

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2007	ALL	Body	Lift Gate Module																																																												
R	2007	ALL	Body	Park Assist Module																																																												
R	2007	ALL	Body	Passenger Door Switch																																																												
R	2007	ALL	Body	Passenger Presence System																																																												
R	2007	ALL	Body	Radio																																																												
R	2007	ALL	Body	Rear HVAC/RSA																																																												
R	2007	ALL	Body	Rollover Sensor																																																												
R	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2007	ALL	Body	Theft Deterrent Module																																																												
R	2008	ALL	Powertrain	Engine Control Module																																																												
R	2008	ALL	Powertrain	Transmission Control Module																																																												
R	2008	ALL	Chassis	Electronic Brake Control Module																																																												
R	2008	ALL	Body	Body Control Module																																																												
R	2008	ALL	Body	Digital Radio Receiver																																																												
R	2008	ALL	Body	Driver Door Switch																																																												
R	2008	ALL	Body	Head Up Display																																																												
R	2008	ALL	Body	Heated Seat Module																																																												
R	2008	ALL	Body	HVAC Control Module Auto																																																												
R	2008	ALL	Body	HVAC Control Module Manual																																																												
R	2008	ALL	Body	Instrument Panel Cluster																																																												
R	2008	ALL	Body	Lift Gate Module																																																												
R	2008	ALL	Body	Park Assist Module																																																												
R	2008	ALL	Body	Passenger Door Switch																																																												
R	2008	ALL	Body	Passenger Presence System																																																												
R	2008	ALL	Body	Radio																																																												
R	2008	ALL	Body	Rear HVAC/RSA																																																												
R	2008	ALL	Body	Rollover Sensor																																																												
R	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2008	ALL	Body	Theft Deterrent Module																																																												
R	2009	ALL	Powertrain	Engine Control Module																																																												
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2009	ALL	Powertrain	Transmission Control Module																																																												
R	2009	ALL	Chassis	Electronic Brake Control Module																																																												
R	2009	ALL	Body	Body Control Module																																																												
R	2009	ALL	Body	Digital Radio Receiver																																																												
R	2009	ALL	Body	Driver Door Switch																																																												
R	2009	ALL	Body	Head Up Display																																																												
R	2009	ALL	Body	Heated Seat Module																																																												
R	2009	ALL	Body	HVAC Control Module Auto																																																												
R	2009	ALL	Body	HVAC Control Module Manual																																																												
R	2009	ALL	Body	Instrument Panel Cluster																																																												
R	2009	ALL	Body	Lift Gate Module																																																												
R	2009	ALL	Body	Park Assist Module																																																												
R	2009	ALL	Body	Passenger Door Switch																																																												
R	2009	ALL	Body	Passenger Presence System																																																												
R	2009	ALL	Body	Radio																																																												
R	2009	ALL	Body	Rear HVAC/RSA																																																												
R	2009	ALL	Body	Rollover Sensor																																																												
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2009	ALL	Body	Theft Deterrent Module																																																												
R	2010	ALL	Powertrain	Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2010	ALL	Powertrain	Transmission Control Module																																																												
R	2010	ALL	Chassis	Electronic Brake Control Module																																																												
R	2010	ALL	Body	Body Control Module																																																												
R	2010	ALL	Body	Digital Radio Receiver																																																												
R	2010	ALL	Body	Driver Door Switch																																																												
R	2010	ALL	Body	Head Up Display																																																												
R	2010	ALL	Body	Heated Seat Module																																																												
R	2010	ALL	Body	HVAC Control Module Auto																																																												
R	2010	ALL	Body	HVAC Control Module Manual																																																												
R	2010	ALL	Body	Instrument Panel Cluster																																																												
R	2010	ALL	Body	Lift Gate Module																																																												
R	2010	ALL	Body	Park Assist Module																																																												
R	2010	ALL	Body	Passenger Door Switch																																																												
R	2010	ALL	Body	Passenger Presence System																																																												
R	2010	ALL	Body	Radio																																																												
R	2010	ALL	Body	Rear HVAC/RSA																																																												
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2010	ALL	Body	Theft Deterrent Module																																																												
R	2011	ALL	Powertrain	Engine Control Module																																																												
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2011	ALL	Powertrain	Transmission Control Module																																																												
R	2011	ALL	Chassis	Electronic Brake Control Module																																																												
R	2011	ALL	Body	Body Control Module																																																												
R	2011	ALL	Body	Digital Radio Receiver																																																												
R	2011	ALL	Body	Driver Door Switch																																																												
R	2011	ALL	Body	Head Up Display																																																												
R	2011	ALL	Body	Heated Seat Module																																																												
R	2011	ALL	Body	HVAC Control Module Auto																																																												
R	2011	ALL	Body	HVAC Control Module Manual																																																												
R	2011	ALL	Body	Instrument Panel Cluster																																																												
R	2011	ALL	Body	Lift Gate Module																																																												
R	2011	ALL	Body	Park Assist Module																																																												
R	2011	ALL	Body	Passenger Door Switch																																																												
R	2011	ALL	Body	Passenger Presence System																																																												
R	2011	ALL	Body	Radio																																																												
R	2011	ALL	Body	Rear HVAC/RSA																																																												
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2011	ALL	Body	Theft Deterrent Module																																																												
R	2012	ALL	Powertrain	Engine Control Module																																																												
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2012	ALL	Powertrain	Transmission Control Module																																																												
R	2012	ALL	Chassis	Electronic Brake Control Module																																																												
R	2012	ALL	Body	Body Control Module																																																												
R	2012	ALL	Body	Digital Radio Receiver																																																												
R	2012	ALL	Body	Driver Door Switch																																																												
R	2012	ALL	Body	Head Up Display																																																												
R	2012	ALL	Body	Heated Seat Module																																																												
R	2012	ALL	Body	HVAC Control Module Auto																																																												
R	2012	ALL	Body	HVAC Control Module Manual																																																												
R	2012	ALL	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2012	ALL	Body	Lift Gate Module																																																									
R	2012	ALL	Body	Park Assist Module																																																									
R	2012	ALL	Body	Passenger Door Switch																																																									
R	2012	ALL	Body	Passenger Presence System																																																									
R	2012	ALL	Body	Radio																																																									
R	2012	ALL	Body	Rear HVAC/RSA																																																									
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2012	ALL	Body	Theft Deterrent Module																																																									
R	2013	ALL	Powertrain	Engine Control Module																																																									
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2013	ALL	Powertrain	Transmission Control Module																																																									
R	2013	ALL	Chassis	Electronic Brake Control Module																																																									
R	2013	ALL	Body	Body Control Module																																																									
R	2013	ALL	Body	Digital Radio Receiver																																																									
R	2013	ALL	Body	Driver Door Switch																																																									
R	2013	ALL	Body	Head Up Display																																																									
R	2013	ALL	Body	Heated Seat Module																																																									
R	2013	ALL	Body	HVAC Control Module Auto																																																									
R	2013	ALL	Body	HVAC Control Module Manual																																																									
R	2013	ALL	Body	Instrument Panel Cluster																																																									
R	2013	ALL	Body	Left Side Object Detection Module																																																									
R	2013	ALL	Body	Lift Gate Module																																																									
R	2013	ALL	Body	Park Assist Module																																																									
R	2013	ALL	Body	Passenger Door Switch																																																									
R	2013	ALL	Body	Passenger Presence System																																																									
R	2013	ALL	Body	Radio																																																									
R	2013	ALL	Body	Rear HVAC/RSA																																																									
R	2013	ALL	Body	Right Side Object Detection Module																																																									
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2013	ALL	Body	Theft Deterrent Module																																																									
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
R	2014	Acadia	Powertrain	Chassis Control Module																																																									
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																									
R	2014	Acadia	Chassis	Electronic Brake Control Module																																																									
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																									
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																									
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
R	2014	Acadia	Body	Passenger Presence Module																																																									
R	2014	Acadia	Body	Instrument Cluster																																																									
R	2014	Acadia	Body	Head-Up Display Module																																																									
R	2014	Acadia	Body	Radio																																																									
R	2014	Acadia	Body	Rear Audio Control Module																																																									
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																									
R	2014	Acadia	Body	Personal Audio Link Control Module																																																									
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																									
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																									
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																									
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																									
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2014	Acadia	Body	Liftgate Control Module																																																									
R	2014	Acadia	Body	Seat Memory Control Module																																																										
R	2014	Acadia	Body	Front Seat Heating Control Module																																																										
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																										
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																										
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																										
R	2014	Acadia	Body	Parking Assist Control Module																																																										
R	2014	Acadia	Body	Frontview Camera Module																																																										
R	2014	Acadia	Body	Theft Deterrent Module																																																										
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
R	2015	Acadia	Chassis	Electronic Brake Control Module																																																										
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2015	Acadia	Body	Passenger Presence Module																																																										
R	2015	Acadia	Body	Instrument Cluster																																																										
R	2015	Acadia	Body	Head-Up Display Module																																																										
R	2015	Acadia	Body	Radio																																																										
R	2015	Acadia	Body	Rear Audio Control Module																																																										
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																										
R	2015	Acadia	Body	Personal Audio Link Control Module																																																										
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																										
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																										
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																										
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
R	2015	Acadia	Body	Liftgate Control Module																																																										
R	2015	Acadia	Body	Seat Memory Control Module																																																										
R	2015	Acadia	Body	Front Seat Heating Control Module																																																										
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																										
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																										
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																										
R	2015	Acadia	Body	Parking Assist Control Module																																																										
R	2015	Acadia	Body	Frontview Camera Module																																																										
R	2015	Acadia	Body	Theft Deterrent Module																																																										
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
R	2016	Acadia	Chassis	Electronic Brake Control Module																																																										
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
R	2016	Acadia	Body	Passenger Presence Module																																																										
R	2016	Acadia	Body	Instrument Cluster																																																										
R	2016	Acadia	Body	Head-Up Display Module																																																										
R	2016	Acadia	Body	Radio																																																										
R	2016	Acadia	Body	Rear Audio Control Module																																																										
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
R	2016	Acadia	Body	Personal Audio Link Control Module																																																									
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																										
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																										
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
R	2016	Acadia	Body	Liftgate Control Module																																																										
R	2016	Acadia	Body	Seat Memory Control Module																																																										
R	2016	Acadia	Body	Front Seat Heating Control Module																																																										
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																										
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																										
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																										
R	2016	Acadia	Body	Parking Assist Control Module																																																										
R	2016	Acadia	Body	Frontview Camera Module																																																										
R	2016	Acadia	Body	Theft Deterrent Module																																																										
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																										
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Sonoma	Body	Body Control Module																																																										
S	2004	Sonoma	Body	Instrument Panel Cluster																																																										
S	2004	Sonoma	Body	Base Radio																																																										
S	2004	Sonoma	Body	Uplevel Radio																																																										
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																										
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2004	Canyon	Chassis	ABS Without Traction Control																																																										
S	2004	Canyon	Chassis	ABS With Traction Control																																																										
S	2004	Canyon	Body	Body Control Module																																																										
S	2004	Canyon	Body	Instrument Panel Cluster																																																										
S	2004	Canyon	Body	OnStar																																																										
S	2004	Canyon	Body	Base Radio																																																										
S	2004	Canyon	Body	Uplevel Radio																																																										
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy	Body	Amplifier (Bose)																																																										
S	2004	Envoy	Body	Body Control Module																																																										
S	2004	Envoy	Body	Driver Door Module																																																										
S	2004	Envoy	Body	Driver Seat Module																																																										
S	2004	Envoy	Body	Heating and Air Conditioning Auto																																																										
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy	Body	Instrument Panel Cluster																																																										
S	2004	Envoy	Body	Lift Gate Module																																																										
S	2004	Envoy	Body	OnStar																																																										
S	2004	Envoy	Body	Passenger Door Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2004	Envoy	Body	Uplevel Radio																																																										
S	2004	Envoy	Body	Navigation Radio																																																										
S	2004	Envoy	Body	Rear Seat Audio																																																										
S	2004	Envoy	Body	Rear Seat Entertainment																																																										
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy XL	Body	Amplifier (Bose)																																																										
S	2004	Envoy XL	Body	Body Control Module																																																										
S	2004	Envoy XL	Body	Driver Door Module																																																										
S	2004	Envoy XL	Body	Driver Seat Module																																																										
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																										
S	2004	Envoy XL	Body	Lift Gate Module																																																										
S	2004	Envoy XL	Body	OnStar																																																										
S	2004	Envoy XL	Body	Passenger Door Module																																																										
S	2004	Envoy XL	Body	Uplevel Radio																																																										
S	2004	Envoy XL	Body	Navigation Radio																																																										
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
S	2004	Envoy XL	Body	Rear HVAC Manual																																																										
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																										
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																										
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																										
S	2004	Envoy XUV	Body	Body Control Module																																																										
S	2004	Envoy XUV	Body	Driver Door Module																																																										
S	2004	Envoy XUV	Body	Driver Seat Module																																																										
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																										
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																										
S	2004	Envoy XUV	Body	Lift Gate Module																																																										
S	2004	Envoy XUV	Body	OnStar																																																										
S	2004	Envoy XUV	Body	Passenger Door Module																																																										
S	2004	Envoy XUV	Body	Uplevel Radio																																																										
S	2004	Envoy XUV	Body	Navigation Radio																																																										
S	2004	Envoy XUV	Body	Rear Seat Audio																																																										
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																									
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																										
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Jimmy	Body	Body Control Module																																																										
S	2004	Jimmy	Body	Heating and Air Conditioning																																																										
S	2004	Jimmy	Body	Instrument Panel Cluster																																																										
S	2004	Jimmy	Body	Memory Seat Module																																																										
S	2004	Jimmy	Body	Base Radio																																																										
S	2004	Jimmy	Body	Uplevel Radio																																																										
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2005	Canyon	Chassis	ABS Without Traction Control																																																										
S	2005	Canyon	Chassis	ABS With Traction Control																																																										
S	2005	Canyon	Body	Body Control Module																																																										
S	2005	Canyon	Body	Instrument Panel Cluster																																																										
S	2005	Canyon	Body	Base Radio																																																										
S	2005	Canyon	Body	Uplevel Radio																																																										
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy	Body	Body Control Module																																																										
S	2005	Envoy	Body	Disc Player and Video Display																																																										
S	2005	Envoy	Body	Driver Door Module																																																										
S	2005	Envoy	Body	Driver Seat Module																																																										
S	2005	Envoy	Body	Heating and Air Conditioning Auto																																																										
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy	Body	Instrument Panel Cluster																																																										
S	2005	Envoy	Body	Lift Gate Module																																																										
S	2005	Envoy	Body	Passenger Door Module																																																										
S	2005	Envoy	Body	Passenger Presence System																																																										
S	2005	Envoy	Body	Uplevel Radio																																																										
S	2005	Envoy	Body	Navigation Radio																																																										
S	2005	Envoy	Body	Rear Seat Audio																																																										
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																													
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																													
S	2005	Envoy XL	Body	Body Control Module																																																													
S	2005	Envoy XL	Body	Disc Player and Video Display																																																													
S	2005	Envoy XL	Body	Driver Door Module																																																													
S	2005	Envoy XL	Body	Driver Seat Module																																																													
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																													
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																													
S	2005	Envoy XL	Body	Instrument Panel Cluster																																																													
S	2005	Envoy XL	Body	Lift Gate Module																																																													
S	2005	Envoy XL	Body	Passenger Door Module																																																													
S	2005	Envoy XL	Body	Passenger Presence System																																																													
S	2005	Envoy XL	Body	Uplevel Radio																																																													
S	2005	Envoy XL	Body	Navigation Radio																																																													
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																													
S	2005	Envoy XL	Body	Rear HVAC Manual																																																													
S	2005	Envoy XL	Body	Rear Seat Audio																																																													
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																													
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																													
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																													
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																													
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																													
S	2005	Envoy XUV	Body	Body Control Module																																																													
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																													
S	2005	Envoy XUV	Body	Driver Door Module																																																													
S	2005	Envoy XUV	Body	Driver Seat Module																																																													
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																													
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																													
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																																													
S	2005	Envoy XUV	Body	Lift Gate Module																																																													
S	2005	Envoy XUV	Body	Passenger Door Module																																																													
S	2005	Envoy XUV	Body	Passenger Presence System																																																													
S	2005	Envoy XUV	Body	Uplevel Radio																																																													
S	2005	Envoy XUV	Body	Navigation Radio																																																													
S	2005	Envoy XUV	Body	Rear Seat Audio																																																													
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																													
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																													
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																													
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																													
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																													
S	2005	Jimmy	Body	Body Control Module																																																													
S	2005	Jimmy	Body	Heating and Air Conditioning																																																													

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2005	Jimmy	Body	Instrument Panel Cluster																																																									
S	2005	Jimmy	Body	Memory Seat Module																																																									
S	2005	Jimmy	Body	Base Radio																																																									
S	2005	Jimmy	Body	Uplevel Radio																																																									
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																									
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																									
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																									
S	2005	Sonoma	Body	Body Control Module																																																									
S	2005	Sonoma	Body	Instrument Panel Cluster																																																									
S	2005	Sonoma	Body	Base Radio																																																									
S	2005	Sonoma	Body	Uplevel Radio																																																									
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																									
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																									
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																									
S	2006	Canyon	Chassis	ABS Without Traction Control																																																									
S	2006	Canyon	Chassis	ABS With Traction Control																																																									
S	2006	Canyon	Body	Body Control Module																																																									
S	2006	Canyon	Body	Instrument Panel Cluster																																																									
S	2006	Canyon	Body	Passenger Presence System																																																									
S	2006	Canyon	Body	Base Radio																																																									
S	2006	Canyon	Body	Uplevel Radio																																																									
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																																									
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																																									
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
S	2006	Envoy	Chassis	ABS/TCS/VSES																																																									
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																									
S	2006	Envoy	Body	Body Control Module																																																									
S	2006	Envoy	Body	Disc Player and Video Display																																																									
S	2006	Envoy	Body	Driver Door Module																																																									
S	2006	Envoy	Body	Driver Seat Module																																																									
S	2006	Envoy	Body	Heating and Air Conditioning Auto																																																									
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																																									
S	2006	Envoy	Body	Instrument Panel Cluster																																																									
S	2006	Envoy	Body	Lift Gate Module																																																									
S	2006	Envoy	Body	Passenger Door Module																																																									
S	2006	Envoy	Body	Passenger Presence System																																																									
S	2006	Envoy	Body	Uplevel Radio																																																									
S	2006	Envoy	Body	Navigation Radio																																																									
S	2006	Envoy	Body	Rear Seat Audio																																																									
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																																									
S	2006	Envoy	Body	Vehicle Theft Deterrent																																																									
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																									
S	2006	Envoy XL	Body	Body Control Module																																																									
S	2006	Envoy XL	Body	Disc Player and Video Display																																																									
S	2006	Envoy XL	Body	Driver Door Module																																																									
S	2006	Envoy XL	Body	Driver Seat Module																																																									
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																									
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																									
S	2006	Envoy XL	Body	Instrument Panel Cluster																																																									
S	2006	Envoy XL	Body	Lift Gate Module																																																									
S	2006	Envoy XL	Body	Passenger Door Module																																																									
S	2006	Envoy XL	Body	Passenger Presence System																																																									
S	2006	Envoy XL	Body	Uplevel Radio																																																									
S	2006	Envoy XL	Body	Navigation Radio																																																									
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																									
S	2006	Envoy XL	Body	Rear HVAC Manual																																																									
S	2006	Envoy XL	Body	Rear Seat Audio																																																									
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																									
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																									
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																									
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																									
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																									
S	2007	Canyon	Body	Body Control Module																																																									
S	2007	Canyon	Body	Digital Radio Receiver																																																									
S	2007	Canyon	Body	Generator Battery Control Module																																																									
S	2007	Canyon	Body	Instrument Panel Cluster																																																									
S	2007	Canyon	Body	Passenger Presence System																																																									
S	2007	Canyon	Body	Base Radio																																																									
S	2007	Canyon	Body	Uplevel Radio																																																									
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																																									
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																																									
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																									
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																									
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
S	2007	Envoy	Chassis	Electronic Brake Control Module																																																									
S	2007	Envoy	Body	Body Control Module																																																									
S	2007	Envoy	Body	Digital Radio Receiver																																																									
S	2007	Envoy	Body	Disc Player and Video Display																																																									
S	2007	Envoy	Body	Driver Door Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2007	Envoy	Body	Driver Seat Module																																																										
S	2007	Envoy	Body	Generator Battery Control Module																																																											
S	2007	Envoy	Body	HVAC Control Module Auto																																																											
S	2007	Envoy	Body	HVAC Control Module Manual																																																											
S	2007	Envoy	Body	Instrument Panel Cluster																																																											
S	2007	Envoy	Body	Lift Gate Module																																																											
S	2007	Envoy	Body	Passenger Door Module																																																											
S	2007	Envoy	Body	Passenger Presence System																																																											
S	2007	Envoy	Body	Uplevel Radio																																																											
S	2007	Envoy	Body	Navigation Radio																																																											
S	2007	Envoy	Body	Rear Seat Audio																																																											
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																																											
S	2007	Envoy	Body	Theft Deterrent Module																																																											
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																																											
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																											
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																											
S	2008	Canyon	Body	Body Control Module																																																											
S	2008	Canyon	Body	Digital Radio Receiver																																																											
S	2008	Canyon	Body	Generator Battery Control Module																																																											
S	2008	Canyon	Body	Instrument Panel Cluster																																																											
S	2008	Canyon	Body	Passenger Presence System																																																											
S	2008	Canyon	Body	Base Radio																																																											
S	2008	Canyon	Body	Uplevel Radio																																																											
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2008	Canyon	Body	Theft Deterrent Module																																																											
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																																											
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2008	Envoy	Chassis	Electronic Brake Control Module																																																											
S	2008	Envoy	Body	Body Control Module																																																											
S	2008	Envoy	Body	Digital Radio Receiver																																																											
S	2008	Envoy	Body	Disc Player and Video Display																																																											
S	2008	Envoy	Body	Driver Door Module																																																											
S	2008	Envoy	Body	Driver Seat Module																																																											
S	2008	Envoy	Body	Generator Battery Control Module																																																											
S	2008	Envoy	Body	HVAC Control Module Auto																																																											
S	2008	Envoy	Body	HVAC Control Module Manual																																																											
S	2008	Envoy	Body	Instrument Panel Cluster																																																											
S	2008	Envoy	Body	Lift Gate Module																																																											
S	2008	Envoy	Body	Passenger Door Module																																																											
S	2008	Envoy	Body	Passenger Presence System																																																											
S	2008	Envoy	Body	Uplevel Radio																																																											
S	2008	Envoy	Body	Navigation Radio																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2008	Envoy	Body	Rear Seat Audio																																																												
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2008	Envoy	Body	Theft Deterrent Module																																																												
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																																												
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																												
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																												
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																												
S	2009	Canyon	Chassis	Electronic Brake Control Module																																																												
S	2009	Canyon	Body	Body Control Module																																																												
S	2009	Canyon	Body	Digital Radio Receiver																																																												
S	2009	Canyon	Body	Generator Battery Control Module																																																												
S	2009	Canyon	Body	Instrument Panel Cluster																																																												
S	2009	Canyon	Body	Passenger Presence System																																																												
S	2009	Canyon	Body	Base Radio																																																												
S	2009	Canyon	Body	Uplevel Radio																																																												
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																																												
S	2009	Canyon	Body	Theft Deterrent Module																																																												
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																												
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																												
S	2009	Envoy	Chassis	Electronic Brake Control Module																																																												
S	2009	Envoy	Body	Body Control Module																																																												
S	2009	Envoy	Body	Digital Radio Receiver																																																												
S	2009	Envoy	Body	Disc Player and Video Display																																																												
S	2009	Envoy	Body	Driver Door Module																																																												
S	2009	Envoy	Body	Driver Seat Module																																																												
S	2009	Envoy	Body	Generator Battery Control Module																																																												
S	2009	Envoy	Body	HVAC Control Module Auto																																																												
S	2009	Envoy	Body	HVAC Control Module Manual																																																												
S	2009	Envoy	Body	Instrument Panel Cluster																																																												
S	2009	Envoy	Body	Lift Gate Module																																																												
S	2009	Envoy	Body	Passenger Door Module																																																												
S	2009	Envoy	Body	Passenger Presence System																																																												
S	2009	Envoy	Body	Uplevel Radio																																																												
S	2009	Envoy	Body	Navigation Radio																																																												
S	2009	Envoy	Body	Rear Seat Audio																																																												
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2009	Envoy	Body	Theft Deterrent Module																																																												
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2010	ALL	Chassis	Electronic Brake Control Module																																																										
S	2010	ALL	Body	Body Control Module																																																									
S	2010	ALL	Body	Digital Radio Receiver																																																									
S	2010	ALL	Body	Generator Battery Control Module																																																									
S	2010	ALL	Body	Instument Panel Cluster																																																									
S	2010	ALL	Body	Passenger Presence System																																																									
S	2010	ALL	Body	Personal Audio Link Module																																																									
S	2010	ALL	Body	Base Radio																																																									
S	2010	ALL	Body	Uplevel Radio																																																									
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
S	2010	ALL	Body	Theft Deterrent Module																																																									
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																									
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Sonoma	Body	Body Control Module																																																									
T	2004	Sonoma	Body	Instrument Panel Cluster																																																									
T	2004	Sonoma	Body	Base Radio																																																									
T	2004	Sonoma	Body	Uplevel Radio																																																									
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																									
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																									
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																									
T	2004	Canyon	Chassis	ABS Without Traction Control																																																									
T	2004	Canyon	Chassis	ABS With Traction Control																																																									
T	2004	Canyon	Body	Body Control Module																																																									
T	2004	Canyon	Body	Instrument Panel Cluster																																																									
T	2004	Canyon	Body	OnStar																																																									
T	2004	Canyon	Body	Base Radio																																																									
T	2004	Canyon	Body	Uplevel Radio																																																									
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																																									
T	2004	Canyon	Body	Instrument Panel Cluster																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																									
T	2004	Envoy	Chassis	ABS Without Traction Control																																																									
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Envoy	Body	Amplifier (Bose)																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2004	Envoy	Body	Body Control Module																																																									
T	2004	Envoy	Body	Driver Door Module																																																										
T	2004	Envoy	Body	Driver Seat Module																																																										
T	2004	Envoy	Body	Heating and Air Conditioning Auto																																																										
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																																										
T	2004	Envoy	Body	Instrument Panel Cluster																																																										
T	2004	Envoy	Body	Lift Gate Module																																																										
T	2004	Envoy	Body	OnStar																																																										
T	2004	Envoy	Body	Passenger Door Module																																																										
T	2004	Envoy	Body	Uplevel Radio																																																										
T	2004	Envoy	Body	Navigation Radio																																																										
T	2004	Envoy	Body	Rear Seat Audio																																																										
T	2004	Envoy	Body	Rear Seat Entertainment																																																										
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy XL	Body	Amplifier (Bose)																																																										
T	2004	Envoy XL	Body	Body Control Module																																																										
T	2004	Envoy XL	Body	Driver Door Module																																																										
T	2004	Envoy XL	Body	Driver Seat Module																																																										
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2004	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2004	Envoy XL	Body	Lift Gate Module																																																										
T	2004	Envoy XL	Body	OnStar																																																										
T	2004	Envoy XL	Body	Passenger Door Module																																																										
T	2004	Envoy XL	Body	Uplevel Radio																																																										
T	2004	Envoy XL	Body	Navigation Radio																																																										
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2004	Envoy XL	Body	Rear HVAC Manual																																																										
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																										
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2004	Envoy XUV	Body	Body Control Module																																																												
T	2004	Envoy XUV	Body	Driver Door Module																																																													
T	2004	Envoy XUV	Body	Driver Seat Module																																																													
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																													
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																													
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																																													
T	2004	Envoy XUV	Body	Lift Gate Module																																																													
T	2004	Envoy XUV	Body	OnStar																																																													
T	2004	Envoy XUV	Body	Passenger Door Module																																																													
T	2004	Envoy XUV	Body	Uplevel Radio																																																													
T	2004	Envoy XUV	Body	Navigation Radio																																																													
T	2004	Envoy XUV	Body	Rear Seat Audio																																																													
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																													
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																													
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																													
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																													
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																													
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																													
T	2004	Jimmy	Body	Body Control Module																																																													
T	2004	Jimmy	Body	Heating and Air Conditioning																																																													
T	2004	Jimmy	Body	Instrument Panel Cluster																																																													
T	2004	Jimmy	Body	Memory Seat Module																																																													
T	2004	Jimmy	Body	Base Radio																																																													
T	2004	Jimmy	Body	Uplevel Radio																																																													
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																													
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																													
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																													
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																													
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																													
T	2005	Canyon	Chassis	ABS Without Traction Control																																																													
T	2005	Canyon	Chassis	ABS With Traction Control																																																													
T	2005	Canyon	Body	Body Control Module																																																													
T	2005	Canyon	Body	Instrument Panel Cluster																																																													
T	2005	Canyon	Body	Base Radio																																																													
T	2005	Canyon	Body	Uplevel Radio																																																													
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																																													
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																																													
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																												
T	2005	Envoy	Chassis	ABS Without Traction Control																																																													
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																													
T	2005	Envoy	Body	Body Control Module																																																													
T	2005	Envoy	Body	Disc Player and Video Display																																																													
T	2005	Envoy	Body	Driver Door Module																																																													
T	2005	Envoy	Body	Driver Seat Module																																																													
T	2005	Envoy	Body	Heating and Air Conditioning Auto																																																													

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																																									
T	2005	Envoy	Body	Instrument Panel Cluster																																																										
T	2005	Envoy	Body	Lift Gate Module																																																										
T	2005	Envoy	Body	Passenger Door Module																																																										
T	2005	Envoy	Body	Passenger Presence System																																																										
T	2005	Envoy	Body	Uplevel Radio																																																										
T	2005	Envoy	Body	Navigation Radio																																																										
T	2005	Envoy	Body	Rear Seat Audio																																																										
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2005	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy XL	Body	Body Control Module																																																										
T	2005	Envoy XL	Body	Disc Player and Video Display																																																										
T	2005	Envoy XL	Body	Driver Door Module																																																										
T	2005	Envoy XL	Body	Driver Seat Module																																																										
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2005	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2005	Envoy XL	Body	Lift Gate Module																																																										
T	2005	Envoy XL	Body	Passenger Door Module																																																										
T	2005	Envoy XL	Body	Passenger Presence System																																																										
T	2005	Envoy XL	Body	Uplevel Radio																																																										
T	2005	Envoy XL	Body	Navigation Radio																																																										
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2005	Envoy XL	Body	Rear HVAC Manual																																																										
T	2005	Envoy XL	Body	Rear Seat Audio																																																										
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																										
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy XUV	Body	Body Control Module																																																										
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																										
T	2005	Envoy XUV	Body	Driver Door Module																																																										
T	2005	Envoy XUV	Body	Driver Seat Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																										
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																																										
T	2005	Envoy XUV	Body	Lift Gate Module																																																										
T	2005	Envoy XUV	Body	Passenger Door Module																																																										
T	2005	Envoy XUV	Body	Passenger Presence System																																																										
T	2005	Envoy XUV	Body	Uplevel Radio																																																										
T	2005	Envoy XUV	Body	Navigation Radio																																																										
T	2005	Envoy XUV	Body	Rear Seat Audio																																																										
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																										
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																										
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Jimmy	Body	Body Control Module																																																										
T	2005	Jimmy	Body	Heating and Air Conditioning																																																										
T	2005	Jimmy	Body	Instrument Panel Cluster																																																										
T	2005	Jimmy	Body	Memory Seat Module																																																										
T	2005	Jimmy	Body	Base Radio																																																										
T	2005	Jimmy	Body	Uplevel Radio																																																										
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																										
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																										
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Sonoma	Body	Body Control Module																																																										
T	2005	Sonoma	Body	Instrument Panel Cluster																																																										
T	2005	Sonoma	Body	Base Radio																																																										
T	2005	Sonoma	Body	Uplevel Radio																																																										
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																										
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2006	Canyon	Chassis	ABS Without Traction Control																																																										
T	2006	Canyon	Chassis	ABS With Traction Control																																																										
T	2006	Canyon	Body	Body Control Module																																																										
T	2006	Canyon	Body	Instrument Panel Cluster																																																										
T	2006	Canyon	Body	Passenger Presence System																																																										
T	2006	Canyon	Body	Base Radio																																																										
T	2006	Canyon	Body	Uplevel Radio																																																										
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																																										
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2006	Envoy	Chassis	ABS/TCS/VSES																																																										
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																										
T	2006	Envoy	Body	Body Control Module																																																										
T	2006	Envoy	Body	Disc Player and Video Display																																																										
T	2006	Envoy	Body	Driver Door Module																																																										
T	2006	Envoy	Body	Driver Seat Module																																																										
T	2006	Envoy	Body	Heating and Air Conditioning Auto																																																										
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																																										
T	2006	Envoy	Body	Instrument Panel Cluster																																																										
T	2006	Envoy	Body	Lift Gate Module																																																										
T	2006	Envoy	Body	Passenger Door Module																																																										
T	2006	Envoy	Body	Passenger Presence System																																																										
T	2006	Envoy	Body	Uplevel Radio																																																										
T	2006	Envoy	Body	Navigation Radio																																																										
T	2006	Envoy	Body	Rear Seat Audio																																																										
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2006	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																										
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																										
T	2006	Envoy XL	Body	Body Control Module																																																										
T	2006	Envoy XL	Body	Disc Player and Video Display																																																										
T	2006	Envoy XL	Body	Driver Door Module																																																										
T	2006	Envoy XL	Body	Driver Seat Module																																																										
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
T	2006	Envoy XL	Body	Instrument Panel Cluster																																																										
T	2006	Envoy XL	Body	Lift Gate Module																																																										
T	2006	Envoy XL	Body	Passenger Door Module																																																										
T	2006	Envoy XL	Body	Passenger Presence System																																																										
T	2006	Envoy XL	Body	Uplevel Radio																																																										
T	2006	Envoy XL	Body	Navigation Radio																																																										
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
T	2006	Envoy XL	Body	Rear HVAC Manual																																																										
T	2006	Envoy XL	Body	Rear Seat Audio																																																										
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																										
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																										
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																										
T	2007	Canyon	Body	Body Control Module																																																										
T	2007	Canyon	Body	Digital Radio Receiver																																																										
T	2007	Canyon	Body	Generator Battery Control Module																																																										
T	2007	Canyon	Body	Instrument Panel Cluster																																																										
T	2007	Canyon	Body	Passenger Presence System																																																										
T	2007	Canyon	Body	Base Radio																																																										
T	2007	Canyon	Body	Uplevel Radio																																																										
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																										
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																										
T	2007	Envoy	Chassis	Electronic Brake Control Module																																																										
T	2007	Envoy	Body	Body Control Module																																																										
T	2007	Envoy	Body	Digital Radio Receiver																																																										
T	2007	Envoy	Body	Disc Player and Video Display																																																										
T	2007	Envoy	Body	Driver Door Module																																																										
T	2007	Envoy	Body	Driver Seat Module																																																										
T	2007	Envoy	Body	Generator Battery Control Module																																																										
T	2007	Envoy	Body	HVAC Control Module Auto																																																										
T	2007	Envoy	Body	HVAC Control Module Manual																																																										
T	2007	Envoy	Body	Instrument Panel Cluster																																																										
T	2007	Envoy	Body	Lift Gate Module																																																										
T	2007	Envoy	Body	Passenger Door Module																																																										
T	2007	Envoy	Body	Passenger Presence System																																																										
T	2007	Envoy	Body	Uplevel Radio																																																										
T	2007	Envoy	Body	Navigation Radio																																																										
T	2007	Envoy	Body	Rear Seat Audio																																																										
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2007	Envoy	Body	Theft Deterrent Module																																																										
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2008	Canyon	Body	Body Control Module																																																										
T	2008	Canyon	Body	Digital Radio Receiver																																																										
T	2008	Canyon	Body	Generator Battery Control Module																																																										
T	2008	Canyon	Body	Instrument Panel Cluster																																																										
T	2008	Canyon	Body	Passenger Presence System																																																										
T	2008	Canyon	Body	Base Radio																																																										
T	2008	Canyon	Body	Uplevel Radio																																																										
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2008	Canyon	Body	Theft Deterrent Module																																																										
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2008	Envoy	Chassis	Electronic Brake Control Module																																																										
T	2008	Envoy	Body	Body Control Module																																																										
T	2008	Envoy	Body	Digital Radio Receiver																																																										
T	2008	Envoy	Body	Disc Player and Video Display																																																										
T	2008	Envoy	Body	Driver Door Module																																																										
T	2008	Envoy	Body	Driver Seat Module																																																										
T	2008	Envoy	Body	Generator Battery Control Module																																																										
T	2008	Envoy	Body	HVAC Control Module Auto																																																										
T	2008	Envoy	Body	HVAC Control Module Manual																																																										
T	2008	Envoy	Body	Instrument Panel Cluster																																																										
T	2008	Envoy	Body	Lift Gate Module																																																										
T	2008	Envoy	Body	Passenger Door Module																																																										
T	2008	Envoy	Body	Passenger Presence System																																																										
T	2008	Envoy	Body	Uplevel Radio																																																										
T	2008	Envoy	Body	Navigation Radio																																																										
T	2008	Envoy	Body	Rear Seat Audio																																																										
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2008	Envoy	Body	Theft Deterrent Module																																																										
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																										
T	2009	Canyon	Chassis	Electronic Brake Control Module																																																										
T	2009	Canyon	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2009	Canyon	Body	Digital Radio Receiver																																																									
T	2009	Canyon	Body	Generator Battery Control Module																																																									
T	2009	Canyon	Body	Instrument Panel Cluster																																																									
T	2009	Canyon	Body	Passenger Presence System																																																									
T	2009	Canyon	Body	Base Radio																																																									
T	2009	Canyon	Body	Uplevel Radio																																																									
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																																									
T	2009	Canyon	Body	Theft Deterrent Module																																																									
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																									
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																									
T	2009	Envoy	Body	Body Control Module																																																									
T	2009	Envoy	Body	Digital Radio Receiver																																																									
T	2009	Envoy	Body	Disc Player and Video Display																																																									
T	2009	Envoy	Body	Driver Door Module																																																									
T	2009	Envoy	Body	Driver Seat Module																																																									
T	2009	Envoy	Body	Generator Battery Control Module																																																									
T	2009	Envoy	Body	HVAC Control Module Auto																																																									
T	2009	Envoy	Body	HVAC Control Module Manual																																																									
T	2009	Envoy	Body	Instrument Panel Cluster																																																									
T	2009	Envoy	Body	Lift Gate Module																																																									
T	2009	Envoy	Body	Passenger Door Module																																																									
T	2009	Envoy	Body	Passenger Presence System																																																									
T	2009	Envoy	Body	Uplevel Radio																																																									
T	2009	Envoy	Body	Navigation Radio																																																									
T	2009	Envoy	Body	Rear Seat Audio																																																									
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																																									
T	2009	Envoy	Body	Theft Deterrent Module																																																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																									
T	2010	ALL	Chassis	Electronic Brake Control Module																																																									
T	2010	ALL	Body	Body Control Module																																																									
T	2010	ALL	Body	Digital Radio Receiver																																																									
T	2010	ALL	Body	Generator Battery Control Module																																																									
T	2010	ALL	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
T	2010	ALL	Body	Passenger Presence System																																																									
T	2010	ALL	Body	Personal Audio Link Module																																																									
T	2010	ALL	Body	Base Radio																																																									
T	2010	ALL	Body	Uplevel Radio																																																									
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
T	2010	ALL	Body	Theft Deterrent Module																																																									
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																										
V	2007	ALL	Powertrain	Engine Control Module																																																										
V	2007	ALL	Powertrain	Rear Drive System																																																										
V	2007	ALL	Powertrain	Transmission Control Module																																																										
V	2007	ALL	Chassis	Electronic Brake Control Module																																																										
V	2007	ALL	Body	Body Control Module																																																										
V	2007	ALL	Body	Digital Radio Receiver																																																										
V	2007	ALL	Body	Driver Door Switch																																																										
V	2007	ALL	Body	Head Up Display																																																										
V	2007	ALL	Body	Heated Seat Module																																																										
V	2007	ALL	Body	HVAC Control Module Auto																																																										
V	2007	ALL	Body	HVAC Control Module Manual																																																										
V	2007	ALL	Body	Instrument Panel Cluster																																																										
V	2007	ALL	Body	Lift Gate Module																																																										
V	2007	ALL	Body	Park Assist Module																																																										
V	2007	ALL	Body	Passenger Door Switch																																																										
V	2007	ALL	Body	Passenger Presence System																																																										
V	2007	ALL	Body	Radio																																																										
V	2007	ALL	Body	Rear HVAC/RSA																																																										
V	2007	ALL	Body	Rollover Sensor																																																										
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2007	ALL	Body	Theft Deterrent Module																																																										
V	2008	ALL	Powertrain	Engine Control Module																																																										
V	2008	ALL	Powertrain	Rear Drive System																																																										
V	2008	ALL	Powertrain	Transmission Control Module																																																										
V	2008	ALL	Chassis	Electronic Brake Control Module																																																										
V	2008	ALL	Body	Body Control Module																																																										
V	2008	ALL	Body	Digital Radio Receiver																																																										
V	2008	ALL	Body	Driver Door Switch																																																										
V	2008	ALL	Body	Head Up Display																																																										
V	2008	ALL	Body	Heated Seat Module																																																										
V	2008	ALL	Body	HVAC Control Module Auto																																																										
V	2008	ALL	Body	HVAC Control Module Manual																																																										
V	2008	ALL	Body	Instrument Panel Cluster																																																										
V	2008	ALL	Body	Lift Gate Module																																																										
V	2008	ALL	Body	Park Assist Module																																																										
V	2008	ALL	Body	Passenger Door Switch																																																										
V	2008	ALL	Body	Passenger Presence System																																																										
V	2008	ALL	Body	Radio																																																										
V	2008	ALL	Body	Rear HVAC/RSA																																																										
V	2008	ALL	Body	Rollover Sensor																																																										
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2008	ALL	Body	Theft Deterrent Module																																																										
V	2009	ALL	Powertrain	Engine Control Module																																																										
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
V	2009	ALL	Powertrain	Rear Drive System																																																											
V	2009	ALL	Powertrain	Transmission Control Module																																																												
V	2009	ALL	Chassis	Electronic Brake Control Module																																																												
V	2009	ALL	Body	Body Control Module																																																											
V	2009	ALL	Body	Digital Radio Receiver																																																											
V	2009	ALL	Body	Driver Door Switch																																																											
V	2009	ALL	Body	Head Up Display																																																											
V	2009	ALL	Body	Heated Seat Module																																																											
V	2009	ALL	Body	HVAC Control Module Auto																																																											
V	2009	ALL	Body	HVAC Control Module Manual																																																											
V	2009	ALL	Body	Instrument Panel Cluster																																																											
V	2009	ALL	Body	Lift Gate Module																																																											
V	2009	ALL	Body	Park Assist Module																																																											
V	2009	ALL	Body	Passenger Door Switch																																																											
V	2009	ALL	Body	Passenger Presence System																																																											
V	2009	ALL	Body	Radio																																																											
V	2009	ALL	Body	Rear HVAC/RSA																																																											
V	2009	ALL	Body	Rollover Sensor																																																											
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2009	ALL	Body	Theft Deterrent Module																																																											
V	2010	ALL	Powertrain	Engine Control Module																																																											
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2010	ALL	Powertrain	Rear Drive System																																																											
V	2010	ALL	Powertrain	Transmission Control Module																																																											
V	2010	ALL	Chassis	Electronic Brake Control Module																																																											
V	2010	ALL	Body	Body Control Module																																																											
V	2010	ALL	Body	Digital Radio Receiver																																																											
V	2010	ALL	Body	Driver Door Switch																																																											
V	2010	ALL	Body	Head Up Display																																																											
V	2010	ALL	Body	Heated Seat Module																																																											
V	2010	ALL	Body	HVAC Control Module Auto																																																											
V	2010	ALL	Body	HVAC Control Module Manual																																																											
V	2010	ALL	Body	Instrument Panel Cluster																																																											
V	2010	ALL	Body	Lift Gate Module																																																											
V	2010	ALL	Body	Park Assist Module																																																											
V	2010	ALL	Body	Passenger Door Switch																																																											
V	2010	ALL	Body	Passenger Presence System																																																											
V	2010	ALL	Body	Radio																																																											
V	2010	ALL	Body	Rear HVAC/RSA																																																											
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2010	ALL	Body	Theft Deterrent Module																																																											
V	2011	ALL	Powertrain	Engine Control Module																																																											
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2011	ALL	Powertrain	Rear Drive System																																																											
V	2011	ALL	Powertrain	Transmission Control Module																																																											
V	2011	ALL	Chassis	Electronic Brake Control Module																																																											
V	2011	ALL	Body	Body Control Module																																																											
V	2011	ALL	Body	Digital Radio Receiver																																																											
V	2011	ALL	Body	Driver Door Switch																																																											
V	2011	ALL	Body	Head Up Display																																																											
V	2011	ALL	Body	Heated Seat Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
V	2011	ALL	Body	HVAC Control Module Auto																																																												
V	2011	ALL	Body	HVAC Control Module Manual																																																												
V	2011	ALL	Body	Instrument Panel Cluster																																																												
V	2011	ALL	Body	Lift Gate Module																																																												
V	2011	ALL	Body	Park Assist Module																																																												
V	2011	ALL	Body	Passenger Door Switch																																																												
V	2011	ALL	Body	Passenger Presence System																																																												
V	2011	ALL	Body	Radio																																																												
V	2011	ALL	Body	Rear HVAC/RSA																																																												
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2011	ALL	Body	Theft Deterrent Module																																																												
V	2012	ALL	Powertrain	Engine Control Module																																																												
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2012	ALL	Powertrain	Rear Drive System																																																												
V	2012	ALL	Powertrain	Transmission Control Module																																																												
V	2012	ALL	Chassis	Electronic Brake Control Module																																																												
V	2012	ALL	Body	Body Control Module																																																												
V	2012	ALL	Body	Digital Radio Receiver																																																												
V	2012	ALL	Body	Driver Door Switch																																																												
V	2012	ALL	Body	Head Up Display																																																												
V	2012	ALL	Body	Heated Seat Module																																																												
V	2012	ALL	Body	HVAC Control Module Auto																																																												
V	2012	ALL	Body	HVAC Control Module Manual																																																												
V	2012	ALL	Body	Instrument Panel Cluster																																																												
V	2012	ALL	Body	Lift Gate Module																																																												
V	2012	ALL	Body	Park Assist Module																																																												
V	2012	ALL	Body	Passenger Door Switch																																																												
V	2012	ALL	Body	Passenger Presence System																																																												
V	2012	ALL	Body	Radio																																																												
V	2012	ALL	Body	Rear HVAC/RSA																																																												
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2012	ALL	Body	Theft Deterrent Module																																																												
V	2013	ALL	Powertrain	Engine Control Module																																																												
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2013	ALL	Powertrain	Rear Drive System																																																												
V	2013	ALL	Powertrain	Transmission Control Module																																																												
V	2013	ALL	Chassis	Electronic Brake Control Module																																																												
V	2013	ALL	Body	Body Control Module																																																												
V	2013	ALL	Body	Digital Radio Receiver																																																												
V	2013	ALL	Body	Driver Door Switch																																																												
V	2013	ALL	Body	Head Up Display																																																												
V	2013	ALL	Body	Heated Seat Module																																																												
V	2013	ALL	Body	HVAC Control Module Auto																																																												
V	2013	ALL	Body	HVAC Control Module Manual																																																												
V	2013	ALL	Body	Instrument Panel Cluster																																																												
V	2013	ALL	Body	Left Side Object Detection Module																																																												
V	2013	ALL	Body	Lift Gate Module																																																												
V	2013	ALL	Body	Park Assist Module																																																												
V	2013	ALL	Body	Passenger Door Switch																																																												
V	2013	ALL	Body	Passenger Presence System																																																												
V	2013	ALL	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
V	2013	ALL	Body	Rear HVAC/RSA																																																									
V	2013	ALL	Body	Right Side Object Detection Module																																																									
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2013	ALL	Body	Theft Deterrent Module																																																									
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2014	Acadia	Powertrain	Chassis Control Module																																																									
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																									
V	2014	Acadia	Chassis	Electronic Brake Control Module																																																									
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																									
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2014	Acadia	Body	Passenger Presence Module																																																									
V	2014	Acadia	Body	Instrument Cluster																																																									
V	2014	Acadia	Body	Head-Up Display Module																																																									
V	2014	Acadia	Body	Radio																																																									
V	2014	Acadia	Body	Rear Audio Control Module																																																									
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																									
V	2014	Acadia	Body	Personal Audio Link Control Module																																																									
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																									
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																									
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																									
V	2014	Acadia	Body	Liftgate Control Module																																																									
V	2014	Acadia	Body	Seat Memory Control Module																																																									
V	2014	Acadia	Body	Front Seat Heating Control Module																																																									
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																									
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																									
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																									
V	2014	Acadia	Body	Parking Assist Control Module																																																									
V	2014	Acadia	Body	Frontview Camera Module																																																									
V	2014	Acadia	Body	Theft Deterrent Module																																																									
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																									
V	2015	Acadia	Chassis	Electronic Brake Control Module																																																									
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																									
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2015	Acadia	Body	Passenger Presence Module																																																									
V	2015	Acadia	Body	Instrument Cluster																																																									
V	2015	Acadia	Body	Head-Up Display Module																																																									
V	2015	Acadia	Body	Radio																																																									
V	2015	Acadia	Body	Rear Audio Control Module																																																									
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																									
V	2015	Acadia	Body	Personal Audio Link Control Module																																																									
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																											
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																											
V	2015	Acadia	Body	Liftgate Control Module																																																											
V	2015	Acadia	Body	Seat Memory Control Module																																																											
V	2015	Acadia	Body	Front Seat Heating Control Module																																																											
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																											
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																											
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																											
V	2015	Acadia	Body	Parking Assist Control Module																																																											
V	2015	Acadia	Body	Frontview Camera Module																																																											
V	2015	Acadia	Body	Theft Deterrent Module																																																											
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																											
V	2016	Acadia	Chassis	Electronic Brake Control Module																																																											
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																											
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																											
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
V	2016	Acadia	Body	Passenger Presence Module																																																											
V	2016	Acadia	Body	Instrument Cluster																																																											
V	2016	Acadia	Body	Head-Up Display Module																																																											
V	2016	Acadia	Body	Radio																																																											
V	2016	Acadia	Body	Rear Audio Control Module																																																											
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																											
V	2016	Acadia	Body	Personal Audio Link Control Module																																																											
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																											
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																											
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																											
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																											
V	2016	Acadia	Body	Liftgate Control Module																																																											
V	2016	Acadia	Body	Seat Memory Control Module																																																											
V	2016	Acadia	Body	Front Seat Heating Control Module																																																											
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																											
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																											
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																											
V	2016	Acadia	Body	Parking Assist Control Module																																																											
V	2016	Acadia	Body	Frontview Camera Module																																																											
V	2016	Acadia	Body	Theft Deterrent Module																																																											
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																		V							V		V									V	V			V	V		V
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																											V																														
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module			V	V	V	V	V	V																		V							V		V									V	V			V	V		V
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																											V																														
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
1	2011	Sierra	Chassis	Electronic Suspension Control																																																										
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																										
1	2011	Sierra	Body	Amplifier (Bose)																																																										
1	2011	Sierra	Body	Body Control Module																																																										
1	2011	Sierra	Body	Body Control Module (aux.)																																																										
1	2011	Sierra	Body	Digital Radio Receiver																																																										
1	2011	Sierra	Body	Driver Door Switch																																																										
1	2011	Sierra	Body	HVAC Control Module Auto																																																										
1	2011	Sierra	Body	HVAC Control Module Manual																																																										
1	2011	Sierra	Body	Instrument Panel Cluster																																																										
1	2011	Sierra	Body	Memory Seat Module																																																										
1	2011	Sierra	Body	Park Assist Module																																																										
1	2011	Sierra	Body	Passenger Door Switch																																																										
1	2011	Sierra	Body	Passenger Presence System																																																										
1	2011	Sierra	Body	Radio																																																									
1	2011	Sierra	Body	Rear Heated Seat Module																																																										
1	2011	Sierra	Body	Rear HVAC/RSA																																																										
1	2011	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2011	Sierra	Body	Theft Deterrent Module																																																										
1	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																										
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																										
1	2011	Sierra Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2011	Sierra Hybrid	Body	Driver Door Switch																																																										
1	2011	Sierra Hybrid	Body	Heated Seat Module																																																										
1	2011	Sierra Hybrid	Body	HVAC Control Module																																																										
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2011	Sierra Hybrid	Body	Park Assist Module																																																										
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																																										
1	2011	Sierra Hybrid	Body	Passenger Presence System																																																										
1	2011	Sierra Hybrid	Body	Radio																																																										
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2011	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2011	Yukon	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																										
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon	Body	Amplifier (Bose)																																																										
1	2011	Yukon	Body	Assist Step Controller																																																										
1	2011	Yukon	Body	Body Control Module																																																										
1	2011	Yukon	Body	Body Control Module (aux.)																																																										
1	2011	Yukon	Body	Digital Radio Receiver																																																										
1	2011	Yukon	Body	Driver Door Switch																																																										
1	2011	Yukon	Body	HVAC Control Module Auto																																																										
1	2011	Yukon	Body	HVAC Control Module Manual																																																										
1	2011	Yukon	Body	Instrument Panel Cluster																																																										
1	2011	Yukon	Body	Left Side Object Detection Module																																																										
1	2011	Yukon	Body	Lift Gate Module																																																										
1	2011	Yukon	Body	Memory Seat Module																																																										
1	2011	Yukon	Body	Park Assist Module																																																										
1	2011	Yukon	Body	Passenger Door Switch																																																										
1	2011	Yukon	Body	Passenger Presence System																																																										
1	2011	Yukon	Body	Radio																																																										
1	2011	Yukon	Body	Rear Heated Seat Module																																																										
1	2011	Yukon	Body	Rear HVAC/RSA																																																										
1	2011	Yukon	Body	Right Side Object Detection Module																																																										
1	2011	Yukon	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon	Body	Theft Deterrent Module																																																										
1	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2011	Yukon Hybrid	Body	Body Control Module																																																										
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																										
1	2011	Yukon Hybrid	Body	HVAC Control Module																																																										
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
1	2011	Yukon Hybrid	Body	Lift Gate Module																																																										
1	2011	Yukon Hybrid	Body	Park Assist Module																																																										
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2011	Yukon Hybrid	Body	Passenger Presence System																																																										
1	2011	Yukon Hybrid	Body	Radio																																																										
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																										
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon XL	Body	Amplifier (Bose)																																																										
1	2011	Yukon XL	Body	Assist Step Controller																																																										
1	2011	Yukon XL	Body	Body Control Module																																																										
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2011	Yukon XL	Body	Digital Radio Receiver																																																										
1	2011	Yukon XL	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2011	Yukon XL	Body	HVAC Control Module Auto																																																										
1	2011	Yukon XL	Body	HVAC Control Module Manual																																																										
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																										
1	2011	Yukon XL	Body	Left Side Object Detection Module																																																										
1	2011	Yukon XL	Body	Lift Gate Module																																																										
1	2011	Yukon XL	Body	Memory Seat Module																																																										
1	2011	Yukon XL	Body	Park Assist Module																																																										
1	2011	Yukon XL	Body	Passenger Door Switch																																																										
1	2011	Yukon XL	Body	Passenger Presence System																																																										
1	2011	Yukon XL	Body	Radio																																																										
1	2011	Yukon XL	Body	Rear Heated Seat Module																																																										
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																										
1	2011	Yukon XL	Body	Right Side Object Detection Module																																																										
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon XL	Body	Theft Deterrent Module																																																										
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V											V	V			V	V		V
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																													
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V											V	V			V	V		V
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																												V																													
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
1	2012	Sierra	Chassis	Electronic Suspension Control																																																										
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																										
1	2012	Sierra	Body	Amplifier (Bose)																																																										
1	2012	Sierra	Body	Body Control Module																																																										
1	2012	Sierra	Body	Body Control Module (aux.)																																																										
1	2012	Sierra	Body	Digital Radio Receiver																																																										
1	2012	Sierra	Body	Driver Door Switch																																																										
1	2012	Sierra	Body	HVAC Control Module Auto																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2012	Sierra	Body	HVAC Control Module Manual																																																										
1	2012	Sierra	Body	Instrument Panel Cluster																																																										
1	2012	Sierra	Body	Memory Seat Module																																																										
1	2012	Sierra	Body	Park Assist Module																																																										
1	2012	Sierra	Body	Passenger Door Switch																																																										
1	2012	Sierra	Body	Passenger Presence System																																																										
1	2012	Sierra	Body	Radio																																																										
1	2012	Sierra	Body	Navigation Radio																																																										
1	2012	Sierra	Body	Rear Heated Seat Module																																																										
1	2012	Sierra	Body	Rear HVAC/RSA																																																										
1	2012	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2012	Sierra	Body	Theft Deterrent Module																																																										
1	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
1	2012	Sierra Hybrid	Body	Body Control Module																																																										
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2012	Sierra Hybrid	Body	Driver Door Switch																																																										
1	2012	Sierra Hybrid	Body	Heated Seat Module																																																										
1	2012	Sierra Hybrid	Body	HVAC Control Module																																																										
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2012	Sierra Hybrid	Body	Park Assist Module																																																										
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																																										
1	2012	Sierra Hybrid	Body	Passenger Presence System																																																										
1	2012	Sierra Hybrid	Body	Radio																																																										
1	2012	Sierra Hybrid	Body	Navigation Radio																																																										
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2012	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2012	Yukon	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																									
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Yukon	Body	Amplifier (Bose)																																																										
1	2012	Yukon	Body	Assist Step Controller																																																										
1	2012	Yukon	Body	Body Control Module																																																										
1	2012	Yukon	Body	Body Control Module (aux.)																																																										
1	2012	Yukon	Body	Digital Radio Receiver																																																										
1	2012	Yukon	Body	Driver Door Switch																																																										
1	2012	Yukon	Body	HVAC Control Module Auto																																																										
1	2012	Yukon	Body	HVAC Control Module Manual																																																										
1	2012	Yukon	Body	Instrument Panel Cluster																																																										
1	2012	Yukon	Body	Left Side Object Detection Module																																																										
1	2012	Yukon	Body	Lift Gate Module																																																										
1	2012	Yukon	Body	Memory Seat Module																																																										
1	2012	Yukon	Body	Park Assist Module																																																										
1	2012	Yukon	Body	Passenger Door Switch																																																										
1	2012	Yukon	Body	Passenger Presence System																																																										
1	2012	Yukon	Body	Radio																																																										
1	2012	Yukon	Body	Navigation Radio																																																										
1	2012	Yukon	Body	Rear Heated Seat Module																																																										
1	2012	Yukon	Body	Rear HVAC/RSA																																																										
1	2012	Yukon	Body	Right Side Object Detection Module																																																										
1	2012	Yukon	Body	Supplemental Inflatable Restraint																																																										
1	2012	Yukon	Body	Theft Deterrent Module																																																										
1	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																										
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2012	Yukon Hybrid	Body	Body Control Module																																																										
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2012	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2012	Yukon Hybrid	Body	Heated Seat Module																																																										
1	2012	Yukon Hybrid	Body	HVAC Control Module																																																										
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
1	2012	Yukon Hybrid	Body	Lift Gate Module																																																										
1	2012	Yukon Hybrid	Body	Park Assist Module																																																										
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2012	Yukon Hybrid	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2012	Yukon Hybrid	Body	Radio																																																									
1	2012	Yukon Hybrid	Body	Navigation Radio																																																									
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																									
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																									
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																									
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																									
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																									
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																									
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
1	2012	Yukon XL	Body	Amplifier (Bose)																																																									
1	2012	Yukon XL	Body	Assist Step Controller																																																									
1	2012	Yukon XL	Body	Body Control Module																																																									
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																									
1	2012	Yukon XL	Body	Digital Radio Receiver																																																									
1	2012	Yukon XL	Body	Driver Door Switch																																																									
1	2012	Yukon XL	Body	HVAC Control Module Auto																																																									
1	2012	Yukon XL	Body	HVAC Control Module Manual																																																									
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																									
1	2012	Yukon XL	Body	Left Side Object Detection Module																																																									
1	2012	Yukon XL	Body	Lift Gate Module																																																									
1	2012	Yukon XL	Body	Memory Seat Module																																																									
1	2012	Yukon XL	Body	Park Assist Module																																																									
1	2012	Yukon XL	Body	Passenger Door Switch																																																									
1	2012	Yukon XL	Body	Passenger Presence System																																																									
1	2012	Yukon XL	Body	Radio																																																									
1	2012	Yukon XL	Body	Navigation Radio																																																									
1	2012	Yukon XL	Body	Rear Heated Seat Module																																																									
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																									
1	2012	Yukon XL	Body	Right Side Object Detection Module																																																									
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
1	2012	Yukon XL	Body	Theft Deterrent Module																																																									
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V																			V							V		V										V	V			V	V		V
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																											V																														
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																										
1	2013	Sierra	Chassis	Electronic Suspension Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Body	Amplifier (Bose)																																																										
1	2013	Sierra	Body	Body Control Module																																																										
1	2013	Sierra	Body	Body Control Module (aux.)																																																										
1	2013	Sierra	Body	Digital Radio Receiver																																																										
1	2013	Sierra	Body	Driver Door Switch																																																										
1	2013	Sierra	Body	HVAC Control Module Auto																																																										
1	2013	Sierra	Body	HVAC Control Module Manual																																																										
1	2013	Sierra	Body	Instrument Panel Cluster																																																										
1	2013	Sierra	Body	Memory Seat Module																																																										
1	2013	Sierra	Body	Park Assist Module																																																										
1	2013	Sierra	Body	Passenger Door Switch																																																										
1	2013	Sierra	Body	Passenger Presence System																																																										
1	2013	Sierra	Body	Radio																																																										
1	2013	Sierra	Body	Navigation Radio																																																										
1	2013	Sierra	Body	Rear Heated Seat Module																																																										
1	2013	Sierra	Body	Rear HVAC/RSA																																																										
1	2013	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2013	Sierra	Body	Theft Deterrent Module																																																										
1	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																										
1	2013	Sierra Hybrid	Body	Body Control Module																																																										
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2013	Sierra Hybrid	Body	Driver Door Switch																																																										
1	2013	Sierra Hybrid	Body	Heated Seat Module																																																										
1	2013	Sierra Hybrid	Body	HVAC Control Module																																																										
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2013	Sierra Hybrid	Body	Park Assist Module																																																										
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																																										
1	2013	Sierra Hybrid	Body	Passenger Presence System																																																										
1	2013	Sierra Hybrid	Body	Radio																																																										
1	2013	Sierra Hybrid	Body	Navigation Radio																																																										
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																										
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2013	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2013	Yukon	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon	Body	Amplifier (Bose)																																																										
1	2013	Yukon	Body	Assist Step Controller																																																										
1	2013	Yukon	Body	Body Control Module																																																										
1	2013	Yukon	Body	Body Control Module (aux.)																																																										
1	2013	Yukon	Body	Digital Radio Receiver																																																										
1	2013	Yukon	Body	Driver Door Switch																																																										
1	2013	Yukon	Body	HVAC Control Module Auto																																																										
1	2013	Yukon	Body	HVAC Control Module Manual																																																										
1	2013	Yukon	Body	Instrument Panel Cluster																																																										
1	2013	Yukon	Body	Left Side Object Detection Module																																																										
1	2013	Yukon	Body	Lift Gate Module																																																										
1	2013	Yukon	Body	Memory Seat Module																																																										
1	2013	Yukon	Body	Park Assist Module																																																										
1	2013	Yukon	Body	Passenger Door Switch																																																										
1	2013	Yukon	Body	Passenger Presence System																																																										
1	2013	Yukon	Body	Radio																																																										
1	2013	Yukon	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2013	Yukon	Body	Rear Heated Seat Module																																																												
1	2013	Yukon	Body	Rear HVAC/RSA																																																												
1	2013	Yukon	Body	Right Side Object Detection Module																																																												
1	2013	Yukon	Body	Supplemental Inflatable Restraint																																																												
1	2013	Yukon	Body	Theft Deterrent Module																																																												
1	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																												
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																												
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																												
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																												
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																												
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																												
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																												
1	2013	Yukon Hybrid	Body	Body Control Module																																																												
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																												
1	2013	Yukon Hybrid	Body	Driver Door Switch																																																												
1	2013	Yukon Hybrid	Body	Heated Seat Module																																																												
1	2013	Yukon Hybrid	Body	HVAC Control Module																																																												
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
1	2013	Yukon Hybrid	Body	Lift Gate Module																																																												
1	2013	Yukon Hybrid	Body	Park Assist Module																																																												
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																																												
1	2013	Yukon Hybrid	Body	Passenger Presence System																																																												
1	2013	Yukon Hybrid	Body	Radio																																																												
1	2013	Yukon Hybrid	Body	Navigation Radio																																																												
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																												
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon XL	Body	Amplifier (Bose)																																																										
1	2013	Yukon XL	Body	Assist Step Controller																																																										
1	2013	Yukon XL	Body	Body Control Module																																																										
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2013	Yukon XL	Body	Digital Radio Receiver																																																										
1	2013	Yukon XL	Body	Driver Door Switch																																																										
1	2013	Yukon XL	Body	HVAC Control Module Auto																																																										
1	2013	Yukon XL	Body	HVAC Control Module Manual																																																										
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																										
1	2013	Yukon XL	Body	Left Side Object Detection Module																																																										
1	2013	Yukon XL	Body	Lift Gate Module																																																										
1	2013	Yukon XL	Body	Memory Seat Module																																																										
1	2013	Yukon XL	Body	Park Assist Module																																																										
1	2013	Yukon XL	Body	Passenger Door Switch																																																										
1	2013	Yukon XL	Body	Passenger Presence System																																																										
1	2013	Yukon XL	Body	Radio																																																										
1	2013	Yukon XL	Body	Navigation Radio																																																										
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																										
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																										
1	2013	Yukon XL	Body	Right Side Object Detection Module																																																										
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
1	2013	Yukon XL	Body	Theft Deterrent Module																																																										
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2014	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2014	Sierra	Chassis	Parking Brake Control Module																																																										
1	2014	Sierra	Chassis	Power Steering Control Module																																																										
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2014	Sierra	Body	Body Control Module																																																										
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Sierra	Body	Passenger Presence Module																																																										
1	2014	Sierra	Body	Instrument Cluster																																																										
1	2014	Sierra	Body	Radio Control																																																										
1	2014	Sierra	Body	HVAC Control																																																										
1	2014	Sierra	Body	Radio																																																										
1	2014	Sierra	Body	Amplifier																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2014	Sierra	Body	Media Disc Player																																																							
1	2014	Sierra	Body	Human Machine Interface Control Module																																																							
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																						
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																						
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																						
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																						
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																						
1	2014	Sierra	Body	Parking Assist Control Module																																																						
1	2014	Sierra	Body	Frontview Camera Module																																																						
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																						
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																						
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																						
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																						
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																						
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																	V		V								V						V	V	V	V
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																											V																							V	V	V	V
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																						
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																						
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																						
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																						
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																						
1	2014	Sierra HD	Chassis	Suspension Control Module																																																						
1	2014	Sierra HD	Body	Body Control Module																																																						
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
1	2014	Sierra HD	Body	Instrument Cluster																																																						
1	2014	Sierra HD	Body	Base Radio																																																						
1	2014	Sierra HD	Body	Navigation Radio																																																						
1	2014	Sierra HD	Body	Uplevel Radio																																																						
1	2014	Sierra HD	Body	Amplifier																																																						
1	2014	Sierra HD	Body	Rear Audio Control Module																																																						
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																						
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																						
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																						
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																						
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																						
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																						
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																						
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																						
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																						
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																						
1	2014	Sierra HD	Body	Seat Memory Control Module																																																						
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																						
1	2014	Sierra HD	Body	Parking Assist Control Module																																																						
1	2014	Sierra HD	Body	Theft Deterrent Module																																																						
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																						
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																						
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																						
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																						
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																						
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																						
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																						

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2014	Yukon	Chassis	Electronic Brake Control Module																																																												
1	2014	Yukon	Chassis	Parking Brake Control Module																																																												
1	2014	Yukon	Chassis	Suspension Control Module																																																												
1	2014	Yukon	Body	Body Control Module																																																												
1	2014	Yukon	Body	Auxiliary Body Control Module																																																												
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	Yukon	Body	Passenger Presence Module																																																												
1	2014	Yukon	Body	Instrument Cluster																																																												
1	2014	Yukon	Body	Base Radio																																																												
1	2014	Yukon	Body	Navigation Radio																																																												
1	2014	Yukon	Body	Uplevel Radio																																																												
1	2014	Yukon	Body	Amplifier																																																												
1	2014	Yukon	Body	Rear Audio Control Module																																																												
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																																												
1	2014	Yukon	Body	Personal Audio Link Control Module																																																												
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																												
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																												
1	2014	Yukon	Body	Liftgate Control Module																																																												
1	2014	Yukon	Body	Seat Memory Control Module																																																												
1	2014	Yukon	Body	Rear Seat Heating Control Module																																																												
1	2014	Yukon	Body	Assist Step Control Module																																																												
1	2014	Yukon	Body	Right Side Object Detection Control Module																																																												
1	2014	Yukon	Body	Left Side Object Detection Control Module																																																												
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																																												
1	2014	Yukon	Body	Parking Assist Control Module																																																												
1	2014	Yukon	Body	Theft Deterrent Module																																																												
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																												
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																												
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																												
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																												
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																																												
1	2014	Yukon XL	Chassis	Suspension Control Module																																																												
1	2014	Yukon XL	Body	Body Control Module																																																												
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																																												
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	Yukon XL	Body	Passenger Presence Module																																																												
1	2014	Yukon XL	Body	Instrument Cluster																																																												
1	2014	Yukon XL	Body	Base Radio																																																												
1	2014	Yukon XL	Body	Navigation Radio																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2014	Yukon XL	Body	Uplevel Radio																																																									
1	2014	Yukon XL	Body	Amplifier																																																									
1	2014	Yukon XL	Body	Rear Audio Control Module																																																									
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																									
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																																									
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																									
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																									
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																									
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																									
1	2014	Yukon XL	Body	Liftgate Control Module																																																									
1	2014	Yukon XL	Body	Seat Memory Control Module																																																									
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																									
1	2014	Yukon XL	Body	Assist Step Control Module																																																									
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																									
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																									
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																									
1	2014	Yukon XL	Body	Parking Assist Control Module																																																									
1	2014	Yukon XL	Body	Theft Deterrent Module																																																									
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																		V		V								V								V	V	V	V
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																											V																													
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2015	Sierra	Chassis	Electronic Brake Control Module																																																									
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																									
1	2015	Sierra	Chassis	Power Steering Control Module																																																									
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2015	Sierra	Chassis	Suspension Control Module																																																									
1	2015	Sierra	Body	Body Control Module																				V																																				

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Sierra	Body	Passenger Presence Module																																																											
1	2015	Sierra	Body	Instrument Cluster																																																											
1	2015	Sierra	Body	Radio Controls																																																											
1	2015	Sierra	Body	HVAC Controls																																																											
1	2015	Sierra	Body	Radio																																																											
1	2015	Sierra	Body	Amplifier																																																											
1	2015	Sierra	Body	Media Disc Player																																																											
1	2015	Sierra	Body	Human Machine Interface Control Module																																																											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
1	2015	Sierra	Body	Parking Assist Control Module																																																											
1	2015	Sierra	Body	Frontview Camera Module																																																											
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																											
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																											
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																											
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																											
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																											
1	2015	Yukon	Chassis	Electronic Brake Control Module																																																											
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																											
1	2015	Yukon	Chassis	Parking Brake Control Module																																																											
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2015	Yukon	Chassis	Power Steering Control Module																																																											
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2015	Yukon	Chassis	Suspension Control Module																																																											
1	2015	Yukon	Body	Body Control Module																																																											
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	Yukon	Body	Passenger Presence Module																																																											
1	2015	Yukon	Body	Instrument Cluster																																																											
1	2015	Yukon	Body	Radio Controls																																																											
1	2015	Yukon	Body	HVAC Controls																																																											
1	2015	Yukon	Body	Radio																																																											
1	2015	Yukon	Body	Amplifier																																																											
1	2015	Yukon	Body	Media Disc Player																																																											
1	2015	Yukon	Body	Human Machine Interface Control Module																																																											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2015	Yukon	Body	HVAC Control Module																																																									
1	2015	Yukon	Body	Liftgate Control Module																																																										
1	2015	Yukon	Body	Keyless Entry Control Module																																																										
1	2015	Yukon	Body	Assist Step Control Module																																																										
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon	Body	Parking Assist Control Module																																																										
1	2015	Yukon	Body	Frontview Camera Module																																																										
1	2015	Yukon	Body	Steering Column Lock Control Module																																																										
1	2015	Yukon	Body	Battery Energy Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	Yukon XL	Chassis	Power Steering Control Module																																																										
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Yukon XL	Chassis	Suspension Control Module																																																										
1	2015	Yukon XL	Body	Body Control Module																																																										
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Yukon XL	Body	Passenger Presence Module																																																										
1	2015	Yukon XL	Body	Instrument Cluster																																																										
1	2015	Yukon XL	Body	Radio Controls																																																										
1	2015	Yukon XL	Body	HVAC Controls																																																										
1	2015	Yukon XL	Body	Radio																																																										
1	2015	Yukon XL	Body	Amplifier																																																										
1	2015	Yukon XL	Body	Media Disc Player																																																										
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Yukon XL	Body	HVAC Control Module																																																										
1	2015	Yukon XL	Body	Liftgate Control Module																																																										
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
1	2015	Yukon XL	Body	Assist Step Control Module																																																										
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon XL	Body	Parking Assist Control Module																																																										
1	2015	Yukon XL	Body	Frontview Camera Module																																																										
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																							
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																							
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																							
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																							
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																						
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																						
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																						
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																						
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																						
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																						
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																						
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																						
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																						
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																						
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																						
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																	V		V							V						V	V	V	V
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																												V																											
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																						
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																						
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																						
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																						
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																						
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																						
1	2016	Sierra	Chassis	Electronic Brake Control Module																																																						
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																						
1	2016	Sierra	Chassis	Parking Brake Control Module																																																						
1	2016	Sierra	Chassis	Power Steering Control Module																																																						
1	2016	Sierra	Chassis	Power Steering Control Module																																																						
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																						
1	2016	Sierra	Chassis	Suspension Control Module																																																						
1	2016	Sierra	Body	Body Control Module																																																						
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
1	2016	Sierra	Body	Passenger Presence Module																																																						
1	2016	Sierra	Body	Instrument Cluster																																																						
1	2016	Sierra	Body	Radio Controls																																																						
1	2016	Sierra	Body	HVAC Controls																																																						
1	2016	Sierra	Body	Radio (IO3)																																																						
1	2016	Sierra	Body	Radio (IOB)																																																						
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																						
1	2016	Sierra	Body	Amplifier																																																						
1	2016	Sierra	Body	Media Disc Player																																																						
1	2016	Sierra	Body	Human Machine Interface Control Module																																																						
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																						
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																						
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																						
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																						
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																						
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																						
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																						
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																						
1	2016	Sierra	Body	Parking Assist Control Module																																																						

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2016	Sierra	Body	Frontview Camera Module																																																										
1	2016	Sierra	Body	Frontview Camera Module																																																										
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2016	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Yukon	Chassis	Parking Brake Control Module																																																										
1	2016	Yukon	Chassis	Power Steering Control Module																																																										
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Yukon	Chassis	Suspension Control Module																																																										
1	2016	Yukon	Body	Body Control Module																																																										
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Yukon	Body	Passenger Presence Module																																																										
1	2016	Yukon	Body	Instrument Cluster																																																										
1	2016	Yukon	Body	Radio Controls																																																										
1	2016	Yukon	Body	HVAC Controls																																																										
1	2016	Yukon	Body	Radio																																																										
1	2016	Yukon	Body	Amplifier																																																										
1	2016	Yukon	Body	Media Disc Player																																																										
1	2016	Yukon	Body	Human Machine Interface Control Module																																																										
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																										
1	2016	Yukon	Body	HVAC Control Module																																																										
1	2016	Yukon	Body	Liftgate Control Module																																																										
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																										
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																										
1	2016	Yukon	Body	Keyless Entry Control Module																																																										
1	2016	Yukon	Body	Assist Step Control Module																																																										
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2016	Yukon	Body	Parking Assist Control Module																																																										
1	2016	Yukon	Body	Frontview Camera Module																																																										
1	2016	Yukon	Body	Steering Column Lock Control Module																																																										
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2016	Yukon XL	Chassis	Power Steering Control Module																																																										
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Yukon XL	Chassis	Suspension Control Module																																																										
1	2016	Yukon XL	Body	Body Control Module																																																										
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
1	2016	Yukon XL	Body	Passenger Presence Module																																																										
1	2016	Yukon XL	Body	Instrument Cluster																																																										
1	2016	Yukon XL	Body	Radio Controls																																																										
1	2016	Yukon XL	Body	HVAC Controls																																																										
1	2016	Yukon XL	Body	Radio																																																										
1	2016	Yukon XL	Body	Amplifier																																																										
1	2016	Yukon XL	Body	Media Disc Player																																																										
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																										
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																										
1	2016	Yukon XL	Body	HVAC Control Module																																																										
1	2016	Yukon XL	Body	Liftgate Control Module																																																										
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																										
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																										
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																										
1	2016	Yukon XL	Body	Assist Step Control Module																																																										
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2016	Yukon XL	Body	Parking Assist Control Module																																																										
1	2016	Yukon XL	Body	Frontview Camera Module																																																										
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																										
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V											V	V			V	V		V
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																													
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V											V	V			V	V		V
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																												V																													
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
2	2011	Sierra	Chassis	Electronic Suspension Control																																																										
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																										
2	2011	Sierra	Body	Amplifier (Bose)																																																										
2	2011	Sierra	Body	Body Control Module																																																										
2	2011	Sierra	Body	Body Control Module (aux.)																																																										
2	2011	Sierra	Body	Digital Radio Receiver																																																										
2	2011	Sierra	Body	Driver Door Switch																																																										
2	2011	Sierra	Body	HVAC Control Module Auto																																																										
2	2011	Sierra	Body	HVAC Control Module Manual																																																										
2	2011	Sierra	Body	Instrument Panel Cluster																																																										
2	2011	Sierra	Body	Memory Seat Module																																																										
2	2011	Sierra	Body	Park Assist Module																																																										
2	2011	Sierra	Body	Passenger Door Switch																																																										
2	2011	Sierra	Body	Passenger Presence System																																																										
2	2011	Sierra	Body	Radio																																																										
2	2011	Sierra	Body	Rear Heated Seat Module																																																										
2	2011	Sierra	Body	Rear HVAC/RSA																																																										
2	2011	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2011	Sierra	Body	Theft Deterrent Module																																																										
2	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2011	Sierra Hybrid	Body	Body Control Module																																																										
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2011	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2011	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2011	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2011	Sierra Hybrid	Body	Park Assist Module																																																										
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2011	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2011	Sierra Hybrid	Body	Radio																																																										
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2011	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2011	Yukon	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																										
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon	Body	Amplifier (Bose)																																																										
2	2011	Yukon	Body	Assist Step Controller																																																										
2	2011	Yukon	Body	Body Control Module																																																										
2	2011	Yukon	Body	Body Control Module (aux.)																																																										
2	2011	Yukon	Body	Digital Radio Receiver																																																										
2	2011	Yukon	Body	Driver Door Switch																																																										
2	2011	Yukon	Body	HVAC Control Module Auto																																																										
2	2011	Yukon	Body	HVAC Control Module Manual																																																										
2	2011	Yukon	Body	Instrument Panel Cluster																																																										
2	2011	Yukon	Body	Left Side Object Detection Module																																																										
2	2011	Yukon	Body	Lift Gate Module																																																										
2	2011	Yukon	Body	Memory Seat Module																																																										
2	2011	Yukon	Body	Park Assist Module																																																										
2	2011	Yukon	Body	Passenger Door Switch																																																										
2	2011	Yukon	Body	Passenger Presence System																																																										
2	2011	Yukon	Body	Radio																																																										
2	2011	Yukon	Body	Rear Heated Seat Module																																																										
2	2011	Yukon	Body	Rear HVAC/RSA																																																										
2	2011	Yukon	Body	Right Side Object Detection Module																																																										
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2011	Yukon	Body	Theft Deterrent Module																																																										
2	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2011	Yukon Hybrid	Body	Body Control Module																																																											
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																											
2	2011	Yukon Hybrid	Body	Driver Door Switch																																																											
2	2011	Yukon Hybrid	Body	Heated Seat Module																																																											
2	2011	Yukon Hybrid	Body	HVAC Control Module																																																											
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
2	2011	Yukon Hybrid	Body	Lift Gate Module																																																											
2	2011	Yukon Hybrid	Body	Park Assist Module																																																											
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																																											
2	2011	Yukon Hybrid	Body	Passenger Presence System																																																											
2	2011	Yukon Hybrid	Body	Radio																																																											
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																											
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																											
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																											
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																											
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																											
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																											
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																											
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																											
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
2	2011	Yukon XL	Body	Amplifier (Bose)																																																											
2	2011	Yukon XL	Body	Assist Step Controller																																																											
2	2011	Yukon XL	Body	Body Control Module																																																											
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																											
2	2011	Yukon XL	Body	Digital Radio Receiver																																																											
2	2011	Yukon XL	Body	Driver Door Switch																																																											
2	2011	Yukon XL	Body	HVAC Control Module Auto																																																											
2	2011	Yukon XL	Body	HVAC Control Module Manual																																																											
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																											
2	2011	Yukon XL	Body	Left Side Object Detection Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2011	Yukon XL	Body	Lift Gate Module																																																									
2	2011	Yukon XL	Body	Memory Seat Module																																																										
2	2011	Yukon XL	Body	Park Assist Module																																																										
2	2011	Yukon XL	Body	Passenger Door Switch																																																										
2	2011	Yukon XL	Body	Passenger Presence System																																																										
2	2011	Yukon XL	Body	Radio																																																										
2	2011	Yukon XL	Body	Rear Heated Seat Module																																																										
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																										
2	2011	Yukon XL	Body	Right Side Object Detection Module																																																										
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
2	2011	Yukon XL	Body	Theft Deterrent Module																																																										
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V												V	V			V	V		V
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																													
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V												V	V			V	V		V
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																												V																													
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
2	2012	Sierra	Chassis	Electronic Suspension Control																																																										
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																										
2	2012	Sierra	Body	Amplifier (Bose)																																																										
2	2012	Sierra	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2012	Sierra	Body	Body Control Module (aux.)																																																								
2	2012	Sierra	Body	Digital Radio Receiver																																																								
2	2012	Sierra	Body	Driver Door Switch																																																								
2	2012	Sierra	Body	HVAC Control Module Auto																																																								
2	2012	Sierra	Body	HVAC Control Module Manual																																																								
2	2012	Sierra	Body	Instrument Panel Cluster																																																								
2	2012	Sierra	Body	Memory Seat Module																																																								
2	2012	Sierra	Body	Park Assist Module																																																								
2	2012	Sierra	Body	Passenger Door Switch																																																								
2	2012	Sierra	Body	Passenger Presence System																																																								
2	2012	Sierra	Body	Radio																																																								
2	2012	Sierra	Body	Navigation Radio																																																								
2	2012	Sierra	Body	Rear Heated Seat Module																																																								
2	2012	Sierra	Body	Rear HVAC/RSA																																																								
2	2012	Sierra	Body	Supplemental Inflatable Restraint																																																								
2	2012	Sierra	Body	Theft Deterrent Module																																																								
2	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																								
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																								
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																								
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																								
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																								
2	2012	Sierra Hybrid	Body	Body Control Module																																																								
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																								
2	2012	Sierra Hybrid	Body	Driver Door Switch																																																								
2	2012	Sierra Hybrid	Body	Heated Seat Module																																																								
2	2012	Sierra Hybrid	Body	HVAC Control Module																																																								
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
2	2012	Sierra Hybrid	Body	Park Assist Module																																																								
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																																								
2	2012	Sierra Hybrid	Body	Passenger Presence System																																																								
2	2012	Sierra Hybrid	Body	Radio																																																								
2	2012	Sierra Hybrid	Body	Navigation Radio																																																								
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																								
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2012	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2012	Yukon	Chassis	Electronic Suspension Control																																																										
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																										
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Yukon	Body	Amplifier (Bose)																																																										
2	2012	Yukon	Body	Assist Step Controller																																																										
2	2012	Yukon	Body	Body Control Module																																																										
2	2012	Yukon	Body	Body Control Module (aux.)																																																										
2	2012	Yukon	Body	Digital Radio Receiver																																																										
2	2012	Yukon	Body	Driver Door Switch																																																										
2	2012	Yukon	Body	HVAC Control Module Auto																																																										
2	2012	Yukon	Body	HVAC Control Module Manual																																																										
2	2012	Yukon	Body	Instrument Panel Cluster																																																										
2	2012	Yukon	Body	Left Side Object Detection Module																																																										
2	2012	Yukon	Body	Lift Gate Module																																																										
2	2012	Yukon	Body	Memory Seat Module																																																										
2	2012	Yukon	Body	Park Assist Module																																																										
2	2012	Yukon	Body	Passenger Door Switch																																																										
2	2012	Yukon	Body	Passenger Presence System																																																										
2	2012	Yukon	Body	Radio																																																										
2	2012	Yukon	Body	Navigation Radio																																																										
2	2012	Yukon	Body	Rear Heated Seat Module																																																										
2	2012	Yukon	Body	Rear HVAC/RSA																																																										
2	2012	Yukon	Body	Right Side Object Detection Module																																																										
2	2012	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2012	Yukon	Body	Theft Deterrent Module																																																										
2	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2012	Yukon Hybrid	Body	Body Control Module																																																										
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Yukon Hybrid	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2012	Yukon Hybrid	Body	Heated Seat Module																																																										
2	2012	Yukon Hybrid	Body	HVAC Control Module																																																											
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
2	2012	Yukon Hybrid	Body	Lift Gate Module																																																											
2	2012	Yukon Hybrid	Body	Park Assist Module																																																											
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																																											
2	2012	Yukon Hybrid	Body	Passenger Presence System																																																											
2	2012	Yukon Hybrid	Body	Radio																																																											
2	2012	Yukon Hybrid	Body	Navigation Radio																																																											
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																											
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																											
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																											
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
2	2012	Yukon XL	Body	Amplifier (Bose)																																																											
2	2012	Yukon XL	Body	Assist Step Controller																																																											
2	2012	Yukon XL	Body	Body Control Module																																																											
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																											
2	2012	Yukon XL	Body	Digital Radio Receiver																																																											
2	2012	Yukon XL	Body	Driver Door Switch																																																											
2	2012	Yukon XL	Body	HVAC Control Module Auto																																																											
2	2012	Yukon XL	Body	HVAC Control Module Manual																																																											
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																											
2	2012	Yukon XL	Body	Left Side Object Detection Module																																																											
2	2012	Yukon XL	Body	Lift Gate Module																																																											
2	2012	Yukon XL	Body	Memory Seat Module																																																											
2	2012	Yukon XL	Body	Park Assist Module																																																											
2	2012	Yukon XL	Body	Passenger Door Switch																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2012	Yukon XL	Body	Passenger Presence System																																																										
2	2012	Yukon XL	Body	Radio																																																										
2	2012	Yukon XL	Body	Navigation Radio																																																										
2	2012	Yukon XL	Body	Rear Heated Seat Module																																																										
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																										
2	2012	Yukon XL	Body	Right Side Object Detection Module																																																										
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
2	2012	Yukon XL	Body	Theft Deterrent Module																																																										
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V																				V							V		V														V	V	V			V
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																												V																													
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																										
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																										
2	2013	Sierra	Chassis	Electronic Suspension Control																																																										
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra	Body	Amplifier (Bose)																																																										
2	2013	Sierra	Body	Body Control Module																																																										
2	2013	Sierra	Body	Body Control Module (aux.)																																																										
2	2013	Sierra	Body	Digital Radio Receiver																																																										
2	2013	Sierra	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2013	Sierra	Body	HVAC Control Module Auto																																																										
2	2013	Sierra	Body	HVAC Control Module Manual																																																										
2	2013	Sierra	Body	Instrument Panel Cluster																																																										
2	2013	Sierra	Body	Memory Seat Module																																																										
2	2013	Sierra	Body	Park Assist Module																																																										
2	2013	Sierra	Body	Passenger Door Switch																																																										
2	2013	Sierra	Body	Passenger Presence System																																																										
2	2013	Sierra	Body	Radio																																																										
2	2013	Sierra	Body	Navigation Radio																																																										
2	2013	Sierra	Body	Rear Heated Seat Module																																																										
2	2013	Sierra	Body	Rear HVAC/RSA																																																										
2	2013	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2013	Sierra	Body	Theft Deterrent Module																																																										
2	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Sierra Hybrid	Body	Body Control Module																																																										
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2013	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2013	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2013	Sierra Hybrid	Body	Park Assist Module																																																										
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2013	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2013	Sierra Hybrid	Body	Radio																																																										
2	2013	Sierra Hybrid	Body	Navigation Radio																																																										
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																									
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2013	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Body	Amplifier (Bose)																																																										
2	2013	Yukon	Body	Assist Step Controller																																																										
2	2013	Yukon	Body	Body Control Module																																																										
2	2013	Yukon	Body	Body Control Module (aux.)																																																										
2	2013	Yukon	Body	Digital Radio Receiver																																																										
2	2013	Yukon	Body	Driver Door Switch																																																										
2	2013	Yukon	Body	HVAC Control Module Auto																																																										
2	2013	Yukon	Body	HVAC Control Module Manual																																																										
2	2013	Yukon	Body	Instrument Panel Cluster																																																										
2	2013	Yukon	Body	Left Side Object Detection Module																																																										
2	2013	Yukon	Body	Lift Gate Module																																																										
2	2013	Yukon	Body	Memory Seat Module																																																										
2	2013	Yukon	Body	Park Assist Module																																																										
2	2013	Yukon	Body	Passenger Door Switch																																																										
2	2013	Yukon	Body	Passenger Presence System																																																										
2	2013	Yukon	Body	Radio																																																										
2	2013	Yukon	Body	Navigation Radio																																																										
2	2013	Yukon	Body	Rear Heated Seat Module																																																										
2	2013	Yukon	Body	Rear HVAC/RSA																																																										
2	2013	Yukon	Body	Right Side Object Detection Module																																																										
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2013	Yukon	Body	Theft Deterrent Module																																																										
2	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2013	Yukon Hybrid	Body	Body Control Module																																																										
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Yukon Hybrid	Body	Driver Door Switch																																																										
2	2013	Yukon Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2013	Yukon Hybrid	Body	HVAC Control Module																																																										
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
2	2013	Yukon Hybrid	Body	Lift Gate Module																																																										
2	2013	Yukon Hybrid	Body	Park Assist Module																																																										
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																																										
2	2013	Yukon Hybrid	Body	Passenger Presence System																																																										
2	2013	Yukon Hybrid	Body	Radio																																																										
2	2013	Yukon Hybrid	Body	Navigation Radio																																																										
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon XL	Body	Amplifier (Bose)																																																										
2	2013	Yukon XL	Body	Assist Step Controller																																																										
2	2013	Yukon XL	Body	Body Control Module																																																										
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																										
2	2013	Yukon XL	Body	Digital Radio Receiver																																																										
2	2013	Yukon XL	Body	Driver Door Switch																																																										
2	2013	Yukon XL	Body	HVAC Control Module Auto																																																										
2	2013	Yukon XL	Body	HVAC Control Module Manual																																																										
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																										
2	2013	Yukon XL	Body	Left Side Object Detection Module																																																										
2	2013	Yukon XL	Body	Lift Gate Module																																																										
2	2013	Yukon XL	Body	Memory Seat Module																																																										
2	2013	Yukon XL	Body	Park Assist Module																																																										
2	2013	Yukon XL	Body	Passenger Door Switch																																																										
2	2013	Yukon XL	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2013	Yukon XL	Body	Radio																																																								
2	2013	Yukon XL	Body	Navigation Radio																																																								
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																								
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																								
2	2013	Yukon XL	Body	Right Side Object Detection Module																																																								
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
2	2013	Yukon XL	Body	Theft Deterrent Module																																																								
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																								
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2014	Sierra	Chassis	Electronic Brake Control Module																																																								
2	2014	Sierra	Chassis	Parking Brake Control Module																																																								
2	2014	Sierra	Chassis	Power Steering Control Module																																																								
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																								
2	2014	Sierra	Body	Body Control Module																																																								
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
2	2014	Sierra	Body	Passenger Presence Module																																																								
2	2014	Sierra	Body	Instrument Cluster																																																								
2	2014	Sierra	Body	Radio Control																																																								
2	2014	Sierra	Body	HVAC Control																																																								
2	2014	Sierra	Body	Radio																																																								
2	2014	Sierra	Body	Amplifier																																																								
2	2014	Sierra	Body	Media Disc Player																																																								
2	2014	Sierra	Body	Human Machine Interface Control Module																																																								
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																								
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																								
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																								
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																								
2	2014	Sierra	Body	Parking Assist Control Module																																																								
2	2014	Sierra	Body	Frontview Camera Module																																																								
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																	V		V								V						V	V	V	V
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																												V																												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																								
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																								
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																								
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2014	Sierra HD	Chassis	Suspension Control Module																																																								
2	2014	Sierra HD	Body	Body Control Module																																																								
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
2	2014	Sierra HD	Body	Instrument Cluster																																																								
2	2014	Sierra HD	Body	Base Radio																																																								
2	2014	Sierra HD	Body	Navigation Radio																																																								
2	2014	Sierra HD	Body	Uplevel Radio																																																								
2	2014	Sierra HD	Body	Amplifier																																																								
2	2014	Sierra HD	Body	Rear Audio Control Module																																																								
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																								
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																								
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																								
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																								
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																								
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																								
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																								
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																								
2	2014	Sierra HD	Body	Seat Memory Control Module																																																								
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																								
2	2014	Sierra HD	Body	Parking Assist Control Module																																																								
2	2014	Sierra HD	Body	Theft Deterrent Module																																																								
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																								
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																								
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																								
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																								
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																								
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																								
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																								
2	2014	Yukon	Chassis	Parking Brake Control Module																																																								
2	2014	Yukon	Chassis	Suspension Control Module																																																								
2	2014	Yukon	Body	Body Control Module																																																								
2	2014	Yukon	Body	Auxiliary Body Control Module																																																								
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
2	2014	Yukon	Body	Passenger Presence Module																																																								
2	2014	Yukon	Body	Instrument Cluster																																																								
2	2014	Yukon	Body	Base Radio																																																								
2	2014	Yukon	Body	Navigation Radio																																																								
2	2014	Yukon	Body	Uplevel Radio																																																								
2	2014	Yukon	Body	Amplifier																																																								
2	2014	Yukon	Body	Rear Audio Control Module																																																								
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																								
2	2014	Yukon	Body	Personal Audio Link Control Module																																																								
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																								
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																								
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																								
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Yukon	Body	Liftgate Control Module																																																											
2	2014	Yukon	Body	Seat Memory Control Module																																																											
2	2014	Yukon	Body	Rear Seat Heating Control Module																																																											
2	2014	Yukon	Body	Assist Step Control Module																																																											
2	2014	Yukon	Body	Right Side Object Detection Control Module																																																											
2	2014	Yukon	Body	Left Side Object Detection Control Module																																																											
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																											
2	2014	Yukon	Body	Parking Assist Control Module																																																											
2	2014	Yukon	Body	Theft Deterrent Module																																																											
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																											
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																											
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																											
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																											
2	2014	Yukon XL	Chassis	Suspension Control Module																																																											
2	2014	Yukon XL	Body	Body Control Module																																																											
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																											
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2014	Yukon XL	Body	Passenger Presence Module																																																											
2	2014	Yukon XL	Body	Instrument Cluster																																																											
2	2014	Yukon XL	Body	Base Radio																																																											
2	2014	Yukon XL	Body	Navigation Radio																																																											
2	2014	Yukon XL	Body	Uplevel Radio																																																											
2	2014	Yukon XL	Body	Amplifier																																																											
2	2014	Yukon XL	Body	Rear Audio Control Module																																																											
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																											
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																											
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																											
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																											
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																											
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																											
2	2014	Yukon XL	Body	Liftgate Control Module																																																											
2	2014	Yukon XL	Body	Seat Memory Control Module																																																											
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																											
2	2014	Yukon XL	Body	Assist Step Control Module																																																											
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																											
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																											
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																											
2	2014	Yukon XL	Body	Parking Assist Control Module																																																											
2	2014	Yukon XL	Body	Theft Deterrent Module																																																											
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																		V		V								V						V	V	V	V
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																											V																														
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Sierra	Chassis	Electronic Brake Control Module																																																										
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Sierra	Chassis	Power Steering Control Module																																																										
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Sierra	Chassis	Suspension Control Module																																																										
2	2015	Sierra	Body	Body Control Module																				V																							V														
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Sierra	Body	Passenger Presence Module																																																										
2	2015	Sierra	Body	Instrument Cluster																																																										
2	2015	Sierra	Body	Radio Controls																																																										
2	2015	Sierra	Body	HVAC Controls																																																										
2	2015	Sierra	Body	Radio																																																										
2	2015	Sierra	Body	Amplifier																																																										
2	2015	Sierra	Body	Media Disc Player																																																										
2	2015	Sierra	Body	Human Machine Interface Control Module																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2015	Sierra	Body	Parking Assist Control Module																																																										
2	2015	Sierra	Body	Frontview Camera Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																										
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																										
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																										
2	2015	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Yukon	Chassis	Parking Brake Control Module																																																										
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																										
2	2015	Yukon	Chassis	Power Steering Control Module																																																										
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Yukon	Chassis	Suspension Control Module																																																										
2	2015	Yukon	Body	Body Control Module																																																										
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Yukon	Body	Passenger Presence Module																																																										
2	2015	Yukon	Body	Instrument Cluster																																																										
2	2015	Yukon	Body	Radio Controls																																																										
2	2015	Yukon	Body	HVAC Controls																																																										
2	2015	Yukon	Body	Radio																																																										
2	2015	Yukon	Body	Amplifier																																																										
2	2015	Yukon	Body	Media Disc Player																																																										
2	2015	Yukon	Body	Human Machine Interface Control Module																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Yukon	Body	HVAC Control Module																																																										
2	2015	Yukon	Body	Liftgate Control Module																																																										
2	2015	Yukon	Body	Keyless Entry Control Module																																																										
2	2015	Yukon	Body	Assist Step Control Module																																																										
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																										
2	2015	Yukon	Body	Parking Assist Control Module																																																										
2	2015	Yukon	Body	Frontview Camera Module																																																										
2	2015	Yukon	Body	Steering Column Lock Control Module																																																										
2	2015	Yukon	Body	Battery Energy Control Module																																																										
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
2	2015	Yukon XL	Chassis	Power Steering Control Module																																																										
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Yukon XL	Chassis	Suspension Control Module																																																										
2	2015	Yukon XL	Body	Body Control Module																																																										
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Yukon XL	Body	Passenger Presence Module																																																										
2	2015	Yukon XL	Body	Instrument Cluster																																																										
2	2015	Yukon XL	Body	Radio Controls																																																										
2	2015	Yukon XL	Body	HVAC Controls																																																										
2	2015	Yukon XL	Body	Radio																																																										
2	2015	Yukon XL	Body	Amplifier																																																										
2	2015	Yukon XL	Body	Media Disc Player																																																										
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Yukon XL	Body	HVAC Control Module																																																										
2	2015	Yukon XL	Body	Liftgate Control Module																																																										
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
2	2015	Yukon XL	Body	Assist Step Control Module																																																										
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
2	2015	Yukon XL	Body	Parking Assist Control Module																																																										
2	2015	Yukon XL	Body	Frontview Camera Module																																																										
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																		V		V								V							V	V	V	V
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																											V																															
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2016	Sierra	Chassis	Electronic Brake Control Module																																																									
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																									
2	2016	Sierra	Chassis	Parking Brake Control Module																																																									
2	2016	Sierra	Chassis	Power Steering Control Module																																																									
2	2016	Sierra	Chassis	Power Steering Control Module																																																									
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2016	Sierra	Chassis	Suspension Control Module																																																									
2	2016	Sierra	Body	Body Control Module																																																									
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2016	Sierra	Body	Passenger Presence Module																																																									
2	2016	Sierra	Body	Instrument Cluster																																																									
2	2016	Sierra	Body	Radio Controls																																																									
2	2016	Sierra	Body	HVAC Controls																																																									
2	2016	Sierra	Body	Radio (IO3)																																																									
2	2016	Sierra	Body	Radio (IOB)																																																									
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																									
2	2016	Sierra	Body	Amplifier																																																									
2	2016	Sierra	Body	Media Disc Player																																																									
2	2016	Sierra	Body	Human Machine Interface Control Module																																																									
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																									
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																									
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																									
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																									
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																									
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																									
2	2016	Sierra	Body	Parking Assist Control Module																																																									
2	2016	Sierra	Body	Frontview Camera Module																																																									
2	2016	Sierra	Body	Frontview Camera Module																																																									
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2016	Yukon	Chassis	Electronic Brake Control Module																																																									
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																									
2	2016	Yukon	Chassis	Parking Brake Control Module																																																									
2	2016	Yukon	Chassis	Power Steering Control Module																																																									
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2016	Yukon	Chassis	Suspension Control Module																																																									
2	2016	Yukon	Body	Body Control Module																																																									
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2016	Yukon	Body	Passenger Presence Module																																																									
2	2016	Yukon	Body	Instrument Cluster																																																									
2	2016	Yukon	Body	Radio Controls																																																									
2	2016	Yukon	Body	HVAC Controls																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
2	2016	Yukon	Body	Radio																																																								
2	2016	Yukon	Body	Amplifier																																																								
2	2016	Yukon	Body	Media Disc Player																																																								
2	2016	Yukon	Body	Human Machine Interface Control Module																																																								
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																								
2	2016	Yukon	Body	HVAC Control Module																																																								
2	2016	Yukon	Body	Liftgate Control Module																																																								
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																								
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																								
2	2016	Yukon	Body	Keyless Entry Control Module																																																								
2	2016	Yukon	Body	Assist Step Control Module																																																								
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																								
2	2016	Yukon	Body	Parking Assist Control Module																																																								
2	2016	Yukon	Body	Frontview Camera Module																																																								
2	2016	Yukon	Body	Steering Column Lock Control Module																																																								
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																								
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																								
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																								
2	2016	Yukon XL	Chassis	Power Steering Control Module																																																								
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																								
2	2016	Yukon XL	Chassis	Suspension Control Module																																																								
2	2016	Yukon XL	Body	Body Control Module																																																								
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
2	2016	Yukon XL	Body	Passenger Presence Module																																																								
2	2016	Yukon XL	Body	Instrument Cluster																																																								
2	2016	Yukon XL	Body	Radio Controls																																																								
2	2016	Yukon XL	Body	HVAC Controls																																																								
2	2016	Yukon XL	Body	Radio																																																								
2	2016	Yukon XL	Body	Amplifier																																																								
2	2016	Yukon XL	Body	Media Disc Player																																																								
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																								
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																								
2	2016	Yukon XL	Body	HVAC Control Module																																																								
2	2016	Yukon XL	Body	Liftgate Control Module																																																								
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																								
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																								
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																								
2	2016	Yukon XL	Body	Assist Step Control Module																																																								
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																								
2	2016	Yukon XL	Body	Parking Assist Control Module																																																								
2	2016	Yukon XL	Body	Frontview Camera Module																																																								
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																								
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
5	2011	ALL	Chassis	Electronic Brake Control Module																																																												
5	2011	ALL	Body	Body Control Module																																																												
5	2011	ALL	Body	Digital Radio Receiver																																																												
5	2011	ALL	Body	Generator Battery Control Module																																																												
5	2011	ALL	Body	Instrument Panel Cluster																																																												
5	2011	ALL	Body	Passenger Presence System																																																												
5	2011	ALL	Body	Personal Audio Link Module																																																												
5	2011	ALL	Body	Base Radio																																																												
5	2011	ALL	Body	Uplevel Radio																																																												
5	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
5	2011	ALL	Body	Theft Deterrent Module																																																												
5	2011	ALL	Body	Vehicle Comm. Interface Module																																																												
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
5	2012	ALL	Chassis	Electronic Brake Control Module																																																												
5	2012	ALL	Body	Body Control Module																																																												
5	2012	ALL	Body	Digital Radio Receiver																																																												
5	2012	ALL	Body	Generator Battery Control Module																																																												
5	2012	ALL	Body	Instrument Panel Cluster																																																												
5	2012	ALL	Body	Passenger Presence System																																																												
5	2012	ALL	Body	Personal Audio Link Module																																																												
5	2012	ALL	Body	Base Radio																																																												
5	2012	ALL	Body	Uplevel Radio																																																												
5	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
5	2012	ALL	Body	Theft Deterrent Module																																																												
5	2012	ALL	Body	Vehicle Comm. Interface Module																																																												
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																												
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																												
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																												
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																												
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																												
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
5	2015	Canyon	Powertrain	Chassis Control Module																																																												
5	2015	Canyon	Powertrain	Transfer Case Control Module																																																												
5	2015	Canyon	Chassis	Electronic Brake Control Module																																																												
5	2015	Canyon	Chassis	Power Steering Control Module																																																												
5	2015	Canyon	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
5	2015	Canyon	Body	Passenger Presence Module																																																												
5	2015	Canyon	Body	Radio																																																											
5	2015	Canyon	Body	Amplifier																																																											
5	2015	Canyon	Body	Human Machine Interface Control Module																																																											
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																																											
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																											
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																											
5	2015	Canyon	Body	Parking Assist Control Module																																																											
5	2015	Canyon	Body	Frontview Camera Module																																																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																											
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
5	2016	Canyon	Powertrain	Transfer Case Control Module																																																											
5	2016	Canyon	Chassis	Electronic Brake Control Module																																																											
5	2016	Canyon	Chassis	Power Steering Control Module																																																											
5	2016	Canyon	Body	Body Control Module																																																											
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
5	2016	Canyon	Body	Passenger Presence Module																																																											
5	2016	Canyon	Body	Trailer Interface Control Module																																																											
5	2016	Canyon	Body	Radio																																																											
5	2016	Canyon	Body	Amplifier																																																											
5	2016	Canyon	Body	Human Machine Interface Control Module																																																											
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																																											
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																											
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																											
5	2016	Canyon	Body	Frontview Camera Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
6	2011	ALL	Chassis	Electronic Brake Control Module																																																											
6	2011	ALL	Body	Body Control Module																																																											
6	2011	ALL	Body	Digital Radio Receiver																																																											
6	2011	ALL	Body	Generator Battery Control Module																																																											
6	2011	ALL	Body	Instrument Panel Cluster																																																											
6	2011	ALL	Body	Passenger Presence System																																																											
6	2011	ALL	Body	Personal Audio Link Module																																																											
6	2011	ALL	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
6	2011	ALL	Body	Uplevel Radio																																																												
6	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
6	2011	ALL	Body	Theft Deterrent Module																																																												
6	2011	ALL	Body	Vehicle Comm. Interface Module																																																												
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																												
6	2012	ALL	Chassis	Electronic Brake Control Module																																																													
6	2012	ALL	Body	Body Control Module																																																													
6	2012	ALL	Body	Digital Radio Receiver																																																													
6	2012	ALL	Body	Generator Battery Control Module																																																												
6	2012	ALL	Body	Instrument Panel Cluster																																																												
6	2012	ALL	Body	Passenger Presence System																																																												
6	2012	ALL	Body	Personal Audio Link Module																																																												
6	2012	ALL	Body	Base Radio																																																												
6	2012	ALL	Body	Uplevel Radio																																																												
6	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
6	2012	ALL	Body	Theft Deterrent Module																																																												
6	2012	ALL	Body	Vehicle Comm. Interface Module																																																												
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
6	2015	Canyon	Powertrain	Chassis Control Module																																																											
6	2015	Canyon	Powertrain	Transfer Case Control Module																																																											
6	2015	Canyon	Chassis	Electronic Brake Control Module																																																											
6	2015	Canyon	Chassis	Power Steering Control Module																																																											
6	2015	Canyon	Body	Body Control Module																																																											
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
6	2015	Canyon	Body	Passenger Presence Module																																																											
6	2015	Canyon	Body	Radio																																																										
6	2015	Canyon	Body	Amplifier																																																										
6	2015	Canyon	Body	Human Machine Interface Control Module																																																										
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																																										
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
6	2015	Canyon	Body	Parking Assist Control Module																																																										
6	2015	Canyon	Body	Frontview Camera Module																																																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																											
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
6	2016	Canyon	Powertrain	Transfer Case Control Module																																																											
6	2016	Canyon	Chassis	Electronic Brake Control Module																																																											
6	2016	Canyon	Chassis	Power Steering Control Module																																																											
6	2016	Canyon	Body	Body Control Module																																																											
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
6	2016	Canyon	Body	Passenger Presence Module																																																											
6	2016	Canyon	Body	Trailer Interface Control Module																																																											
6	2016	Canyon	Body	Radio																																																											
6	2016	Canyon	Body	Amplifier																																																											
6	2016	Canyon	Body	Human Machine Interface Control Module																																																											
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																																											
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																											
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																											
6	2016	Canyon	Body	Frontview Camera Module																																																											
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																			V							V		V												V	V			V	V		V
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																												V																															
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
7	2011	Express/Savana	Body	Body Control Module																																																											
7	2011	Express/Savana	Body	Digital Radio Receiver																																																											
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																											
7	2011	Express/Savana	Body	Passenger Presence System																																																											
7	2011	Express/Savana	Body	Radio																																																											
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
7	2011	Express/Savana	Body	Rollover Sensor																																																											
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
7	2011	Express/Savana	Body	Theft Deterrent Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																		V							V		V										V	V			V	V		V
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																											V																														
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2011	Express Access/Savana Pro	Body	Body Control Module																																																									
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																									
7	2011	Express Access/Savana Pro	Body	Radio																																																									
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																									
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																		V							V		V										V	V			V	V		V
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																											V																														
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2012	Express/Savana	Body	Body Control Module																																																									
7	2012	Express/Savana	Body	Digital Radio Receiver																																																									
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																									
7	2012	Express/Savana	Body	Passenger Presence System																																																									
7	2012	Express/Savana	Body	Radio																																																									
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
7	2012	Express/Savana	Body	Rollover Sensor																																																									
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
7	2012	Express/Savana	Body	Theft Deterrent Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module			V	V	V	V	V	V																		V							V		V									V	V		V	V		V
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																											V																														
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																									
7	2012	Express Access/Savana Pro	Body	Radio																																																									
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																									
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V																			V							V		V									V	V		V	V		V
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																											V																														
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2013	Express/Savana	Body	Body Control Module																																																									
7	2013	Express/Savana	Body	Digital Radio Receiver																																																									
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																									
7	2013	Express/Savana	Body	Passenger Presence System																																																									
7	2013	Express/Savana	Body	Radio																																																									
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
7	2013	Express/Savana	Body	Rollover Sensor																																																									
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
7	2013	Express/Savana	Body	Theft Deterrent Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V																			V							V		V												V	V			V	V		V
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																											V																															
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2013	Express Access/Savana Pro	Body	Body Control Module																																																									
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																									
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																									
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																									
7	2013	Express Access/Savana Pro	Body	Radio																																																									
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																									
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																									
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																									
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																									
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																									
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																									
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																									
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																									
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V									V						V	V	V	V
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																											V																															
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
7	2014	Savana	Chassis	Electronic Brake Control Module																																																									
7	2014	Savana	Body	Body Control Module																																																									
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
7	2014	Savana	Body	Passenger Presence Module																																																									
7	2014	Savana	Body	Rollover Sensor Module																																																									
7	2014	Savana	Body	Instrument Cluster																																																									
7	2014	Savana	Body	Chime Alarm Control Module																																																									
7	2014	Savana	Body	Base Radio																																																									
7	2014	Savana	Body	Navigation Radio																																																									
7	2014	Savana	Body	Uplevel Radio																																																									
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																									
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																									
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
7	2014	Savana	Body	Auxiliary Heater Control Module																																																							
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																							
7	2014	Savana	Body	Parking Assist Control Module																																																							
7	2014	Savana	Body	Theft Deterrent Module																																																							
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																							
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																							
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																							
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																							
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																							
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																							
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V								V						V	V	V	V
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																												V																											
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																							
7	2015	Savana	Chassis	Electronic Brake Control Module																																																							
7	2015	Savana	Body	Body Control Module																																																							
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
7	2015	Savana	Body	Rollover Sensor Module																																																							
7	2015	Savana	Body	Instrument Cluster																																																							
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																							
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																							
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																							
7	2015	Savana	Body	Auxiliary Heater Control Module																																																							
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																							
7	2015	Savana	Body	Parking Assist Control Module																																																							
7	2015	Savana	Body	Theft Deterrent Module																																																							
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																							
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																							
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																							
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																							
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																							
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																							
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V								V						V	V	V	V
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																												V																											
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																							
7	2016	Savana	Chassis	Electronic Brake Control Module																																																							
7	2016	Savana	Body	Body Control Module																																																							
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
7	2016	Savana	Body	Instrument Cluster																																																							
7	2016	Savana	Body	Chime Alarm Control Module																																																							
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																							
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																							
7	2016	Savana	Body	Auxiliary Heater Control Module																																																							
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																							
7	2016	Savana	Body	Parking Assist Control Module																																																							
7	2016	Savana	Body	Theft Deterrent Module																																																							
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																							
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																							
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																							
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																							
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																							

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2011	Express/Savana	Body	Body Control Module																																																										
8	2011	Express/Savana	Body	Digital Radio Receiver																																																										
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
8	2011	Express/Savana	Body	Passenger Presence System																																																										
8	2011	Express/Savana	Body	Radio																																																										
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
8	2011	Express/Savana	Body	Rollover Sensor																																																										
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
8	2011	Express/Savana	Body	Theft Deterrent Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2011	Express Access/Savana Pro	Body	Body Control Module																																																										
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																										
8	2011	Express Access/Savana Pro	Body	Radio																																																										
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																										
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2012	Express/Savana	Body	Body Control Module																																																										
8	2012	Express/Savana	Body	Digital Radio Receiver																																																										
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																										
8	2012	Express/Savana	Body	Passenger Presence System																																																										
8	2012	Express/Savana	Body	Radio																																																										
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
8	2012	Express/Savana	Body	Rollover Sensor																																																								
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
8	2012	Express/Savana	Body	Theft Deterrent Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
8	2012	Express Access/Savana Pro	Body	Body Control Module																																																								
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																								
8	2012	Express Access/Savana Pro	Body	Radio																																																								
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
8	2013	Express/Savana	Body	Body Control Module																																																								
8	2013	Express/Savana	Body	Digital Radio Receiver																																																								
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
8	2013	Express/Savana	Body	Navigation Radio																																																								
8	2013	Express/Savana	Body	Park Assist Module																																																								
8	2013	Express/Savana	Body	Passenger Presence System																																																								
8	2013	Express/Savana	Body	Radio																																																								
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
8	2013	Express/Savana	Body	Rollover Sensor																																																								
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
8	2013	Express/Savana	Body	Theft Deterrent Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2013	Express Access/Savana Pro	Body	Body Control Module																																																										
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
8	2013	Express Access/Savana Pro	Body	Radio																																																										
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V								V							V	V	V	V
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																											V																														
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
8	2014	Savana	Chassis	Electronic Brake Control Module																																																										
8	2014	Savana	Body	Body Control Module																																																										
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
8	2014	Savana	Body	Passenger Presence Module																																																										
8	2014	Savana	Body	Rollover Sensor Module																																																										
8	2014	Savana	Body	Instrument Cluster																																																										
8	2014	Savana	Body	Chime Alarm Control Module																																																										
8	2014	Savana	Body	Base Radio																																																										
8	2014	Savana	Body	Navigation Radio																																																										
8	2014	Savana	Body	Uplevel Radio																																																										
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
8	2014	Savana	Body	Auxiliary Heater Control Module																																																										
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
8	2014	Savana	Body	Parking Assist Control Module																																																										
8	2014	Savana	Body	Theft Deterrent Module																																																										
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																							
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																							
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V							V						V	V	V	V
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																											V																												
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																						
8	2015	Savana	Chassis	Electronic Brake Control Module																																																						
8	2015	Savana	Body	Body Control Module																																																						
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
8	2015	Savana	Body	Rollover Sensor Module																																																						
8	2015	Savana	Body	Instrument Cluster																																																						
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																						
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																						
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																						
8	2015	Savana	Body	Auxiliary Heater Control Module																																																						
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																						
8	2015	Savana	Body	Parking Assist Control Module																																																						
8	2015	Savana	Body	Theft Deterrent Module																																																						
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																						
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																						
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																						
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																						
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																						
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																						
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																		V		V							V						V	V	V	V
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																											V																												
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																						
8	2016	Savana	Chassis	Electronic Brake Control Module																																																						
8	2016	Savana	Body	Body Control Module																																																						
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																						
8	2016	Savana	Body	Instrument Cluster																																																					
8	2016	Savana	Body	Chime Alarm Control Module																																																					
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																					
8	2016	Savana	Body	Telematics Communication Interface Control Module																																																					
8	2016	Savana	Body	Auxiliary Heater Control Module																																																					
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																					
8	2016	Savana	Body	Parking Assist Control Module																																																					
8	2016	Savana	Body	Theft Deterrent Module																																																					
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																					
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																					
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																					
ALL	2004	ALL	Chassis	ABS																																																					
ALL	2004	ALL	Chassis	Air Suspension																																																					
ALL	2004	ALL	Body	Amplifier (Bose)																																																					
ALL	2004	ALL	Body	Body Control Module																																																					
ALL	2004	ALL	Body	Digital Radio Receiver																																																					
ALL	2004	ALL	Body	Driver Door Module																																																					
ALL	2004	ALL	Body	Driver Seat Module																																																					
ALL	2004	ALL	Body	Heating and Air Conditioning																																																					
ALL	2004	ALL	Body	Instrument Panel Cluster																																																					
ALL	2004	ALL	Body	OnStar																																																					
ALL	2004	ALL	Body	Passenger Door Module																																																					

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
ALL	2004	ALL	Body	Uplevel Radio																																																									
ALL	2004	ALL	Body	Navigation Radio																																																									
ALL	2004	ALL	Body	Rear Seat Audio																																																									
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																									
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									
ALL	2005	ALL	Chassis	ABS																																																									
ALL	2005	ALL	Chassis	Air Suspension																																																									
ALL	2005	ALL	Body	Body Control Module																																																									
ALL	2005	ALL	Body	Digital Radio Receiver																																																									
ALL	2005	ALL	Body	Driver Door Module (SUV)																																																									
ALL	2005	ALL	Body	Driver Door Module (SUT)																																																									
ALL	2005	ALL	Body	Driver Seat Module																																																									
ALL	2005	ALL	Body	Heating and Air Conditioning																																																									
ALL	2005	ALL	Body	Instrument Panel Cluster																																																									
ALL	2005	ALL	Body	Passenger Door Module																																																									
ALL	2005	ALL	Body	Uplevel Radio																																																									
ALL	2005	ALL	Body	Navigation Radio																																																									
ALL	2005	ALL	Body	Rear Seat Audio																																																									
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																									
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									
ALL	2006	H2	Chassis	ABS																																																									
ALL	2006	H2	Chassis	Air Suspension																																																									
ALL	2006	H2	Body	Body Control Module																																																									
ALL	2006	H2	Body	Digital Radio Receiver																																																									
ALL	2006	H2	Body	Driver Door Module (SUV)																																																									
ALL	2006	H2	Body	Driver Door Module (SUT)																																																									
ALL	2006	H2	Body	Driver Seat Module																																																									
ALL	2006	H2	Body	Heating and Air Conditioning																																																									
ALL	2006	H2	Body	Instrument Panel Cluster																																																									
ALL	2006	H2	Body	Passenger Door Module																																																									
ALL	2006	H2	Body	Uplevel Radio																																																									
ALL	2006	H2	Body	Navigation Radio																																																									
ALL	2006	H2	Body	Rear Seat Audio																																																									
ALL	2006	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2006	H3	Powertrain	Engine Control Module																																																									
ALL	2006	H3	Powertrain	Transmission Control Module																																																									
ALL	2006	H3	Powertrain	Transfer Case Control Module																																																									
ALL	2006	H3	Chassis	Antilock Brake System																																																									
ALL	2006	H3	Body	Body Control Module																																																									
ALL	2006	H3	Body	Digital Radio Receiver																																																									
ALL	2006	H3	Body	Instrument Panel Cluster																																																									
ALL	2006	H3	Body	Uplevel Radio																																																									
ALL	2006	H3	Body	Navigation Radio																																																									
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																																									
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																									
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
ALL	2007	H2	Chassis	ABS																																																									
ALL	2007	H2	Chassis	Air Suspension																																																									
ALL	2007	H2	Body	Amplifier (Bose)																																																									
ALL	2007	H2	Body	Body Control Module																																																									
ALL	2007	H2	Body	Digital Radio Receiver																																																									
ALL	2007	H2	Body	Driver Door Module (SUV)																																																									
ALL	2007	H2	Body	Driver Door Module (SUT)																																																									
ALL	2007	H2	Body	Driver Seat Module																																																									
ALL	2007	H2	Body	HVAC Control Module																																																									
ALL	2007	H2	Body	Instrument Panel Cluster																																																									
ALL	2007	H2	Body	Passenger Door Module																																																									
ALL	2007	H2	Body	Uplevel Radio																																																									
ALL	2007	H2	Body	Navigation Radio																																																									
ALL	2007	H2	Body	Rear Seat Audio																																																									
ALL	2007	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																																									
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																									
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																									
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																									
ALL	2007	H3	Chassis	EBCM																																																									
ALL	2007	H3	Body	Body Control Module (5GT)																																																									
ALL	2007	H3	Body	Body Control Module (ADM)																																																									
ALL	2007	H3	Body	Digital Radio Receiver																																																									
ALL	2007	H3	Body	Generator Battery Control Module																																																									
ALL	2007	H3	Body	Instrument Panel Cluster																																																									
ALL	2007	H3	Body	Personal Audio Link Module																																																									
ALL	2007	H3	Body	Uplevel Radio																																																									
ALL	2007	H3	Body	Navigation Radio																																																									
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																																									
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																									
ALL	2008	H2	Chassis	Air SCM																																																									
ALL	2008	H2	Chassis	EBCM																																																									
ALL	2008	H2	Body	Amplifier (Bose)																																																									
ALL	2008	H2	Body	Body Control Module																																																									
ALL	2008	H2	Body	Digital Radio Receiver																																																									
ALL	2008	H2	Body	Driver Door Switch																																																									
ALL	2008	H2	Body	HVAC Control Module																																																									
ALL	2008	H2	Body	Instrument Panel Cluster																																																									
ALL	2008	H2	Body	Memory Seat Module																																																									
ALL	2008	H2	Body	Passenger Door Switch																																																									
ALL	2008	H2	Body	Radio																																																									
ALL	2008	H2	Body	Rear Heated Seat Module																																																									
ALL	2008	H2	Body	Rear HVAC/RSA																																																									
ALL	2008	H2	Body	Rollover Sensor																																																									
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2008	H2	Body	Theft Deterrent Module																																																									
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																																									

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)																																																									
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																																										
ALL	2008	H3	Chassis	EBCM																																																										
ALL	2008	H3	Body	Body Control Module (5GT)																																																										
ALL	2008	H3	Body	Body Control Module (ADM)																																																										
ALL	2008	H3	Body	Digital Radio Receiver																																																										
ALL	2008	H3	Body	Generator Battery Control Module																																																										
ALL	2008	H3	Body	Instrument Panel Cluster																																																										
ALL	2008	H3	Body	Personal Audio Link Module																																																										
ALL	2008	H3	Body	Uplevel Radio																																																										
ALL	2008	H3	Body	Navigation Radio																																																										
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	H3	Body	Theft Deterrent Module																																																										
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2009	H2	Chassis	Air SCM																																																										
ALL	2009	H2	Chassis	EBCM																																																										
ALL	2009	H2	Body	Amplifier (Bose)																																																										
ALL	2009	H2	Body	Body Control Module																																																										
ALL	2009	H2	Body	Digital Radio Receiver																																																										
ALL	2009	H2	Body	Driver Door Switch																																																										
ALL	2009	H2	Body	HVAC Control Module																																																										
ALL	2009	H2	Body	Instrument Panel Cluster																																																										
ALL	2009	H2	Body	Memory Seat Module																																																										
ALL	2009	H2	Body	Passenger Door Switch																																																										
ALL	2009	H2	Body	Radio																																																										
ALL	2009	H2	Body	Rear Heated Seat Module																																																										
ALL	2009	H2	Body	Rear HVAC/RSA																																																										
ALL	2009	H2	Body	Rollover Sensor																																																										
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	H2	Body	Theft Deterrent Module																																																										
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2009	H3	Chassis	EBCM																																																										
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																																										
ALL	2009	H3	Body	Body Control Module (ADM)																																																										
ALL	2009	H3	Body	Digital Radio Receiver																																																										
ALL	2009	H3	Body	Generator Battery Control Module																																																										
ALL	2009	H3	Body	Instrument Panel Cluster																																																										
ALL	2009	H3	Body	Personal Audio Link Module																																																										
ALL	2009	H3	Body	Uplevel Radio																																																										
ALL	2009	H3	Body	Navigation Radio																																																										
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	H3	Body	Theft Deterrent Module																																																										
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2010	H2	Chassis	Air SCM																																																										
ALL	2010	H2	Chassis	EBCM																																																										
ALL	2010	H2	Body	Amplifier (Bose)																																																										
ALL	2010	H2	Body	Body Control Module																																																										
ALL	2010	H2	Body	Digital Radio Receiver																																																										
ALL	2010	H2	Body	Driver Door Switch																																																										
ALL	2010	H2	Body	HVAC Control Module																																																										
ALL	2010	H2	Body	Instrument Panel Cluster																																																										
ALL	2010	H2	Body	Memory Seat Module																																																										
ALL	2010	H2	Body	Passenger Door Switch																																																										
ALL	2010	H2	Body	Personal Audio Link Module																																																										
ALL	2010	H2	Body	Radio																																																										
ALL	2010	H2	Body	Rear Heated Seat Module																																																										
ALL	2010	H2	Body	Rear HVAC/RSA																																																										
ALL	2010	H2	Body	Rollover Sensor																																																										
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	H2	Body	Theft Deterrent Module																																																										
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2010	H3	Chassis	EBCM																																																										
ALL	2010	H3	Body	Body Control Module																																																										
ALL	2010	H3	Body	Digital Radio Receiver																																																										
ALL	2010	H3	Body	Generator Battery Control Module																																																										
ALL	2010	H3	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	DPF Reset Replace DPF	DPF Reset Replace Injectors	Reset Injection Value - Cyl. 1	Reset Injection Value - Cyl. 2	Reset Injection Value - Cyl. 3	Reset Injection Value - Cyl. 4	Reset Injection Value - All Cyl.	Reset Injection Value - ECM	Data List 1	Data List 2	Crankshaft possition variation learn	Fuel trim reset	Engine Overspeed Data	Engine Oil Level Warning Event Data	DPF Pressure sensor learn	Fuel injector learn	Fuel rail pressure sensor or fuel rail learn	DPF reset	Engine oil life reset	Exterior Lighting 2 Data	Driver SBR Control	Passenger SBR Control	Misfire Graphic	Engine Overspeed Event Data	Fuel Injector Balance	Brake pedal position sensor learn	Engine Speed Control Data	Glow Plug Data	Fuel Pressure Regulator Learn	Fuel Pressure Regulator Fast Learn	HO2S Learn	Intake Manifold Runner Control Valve Learn	High Pressure Fuel Pump Learn	Boost Pressure Sensor Learn	DPF Pressure Sensor Reset	DPF Reset	DPF Service Regeneration	Injector flow rate programming	Fuel composition reset	Fuel injector balance	Intake Air Flow Valve Learn	Stop/Start Select Switch Indicator	Seat Heating/Venting/Cooling Data	Auxiliary Heater Data	Idle Air Control Reset	Crankshaft Position Reluctor Wheel Learn	Combustion Control System Data	Engine Mechanical Data	Engine Position Data	Reductant System Data	Catalyst Reset	Exhaust Gas Temperature Sensor Reset	Fuel Filter Life Reset	NOx Catalyst Reset	NOx Catalyst Reductant Loading Reset	NOx Sensor 1 Reset
ALL	2010	H3	Body	Personal Audio Link Module		

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																																																										
C	2004	ALL	Body	Body Control Module																																																									
C	2004	ALL	Body	CD Changer																																																									
C	2004	ALL	Body	Chime																																																									
C	2004	ALL	Body	Driver Door Module																																																									
C	2004	ALL	Body	Driver Seat Module																																																									
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2004	ALL	Body	Instrument Panel Cluster																																																										
C	2004	ALL	Body	OnStar																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2004	ALL	Body	Passenger Door Module																																																										
C	2004	ALL	Body	Passenger Presence System																																																										
C	2004	ALL	Body	Radio Base																																																										
C	2004	ALL	Body	Radio Uplevel																																																										
C	2004	ALL	Body	Radio Navigation																																																										
C	2004	ALL	Body	Rear Aux. Climate Module																																																										
C	2004	ALL	Body	Rear HVAC																																																										
C	2004	ALL	Body	Rear Seat Audio																																																								V			
C	2004	ALL	Body	Rear Seat Entertainment																																																										
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2004	ALL	Body	Vehicle Theft Deterrent																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2005	ALL	Chassis	ESC																																																										
C	2005	ALL	Chassis	Rear Wheel Steering																																																										
C	2005	ALL	Chassis	Tire Pressure Monitor																																																										
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2005	ALL	Chassis	VSES																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2005	ALL	Body	Amplifier (Bose)																																																											
C	2005	ALL	Body	Body Control Module																																																											
C	2005	ALL	Body	CD Changer																																																											
C	2005	ALL	Body	Chime																																																											
C	2005	ALL	Body	Disc Player and Video Display																																																												
C	2005	ALL	Body	Driver Door Module																																																												
C	2005	ALL	Body	Driver Seat Module																																																												
C	2005	ALL	Body	Generator Battery Control Module																																																												
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																												
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																												
C	2005	ALL	Body	Instrument Panel Cluster																																																												
C	2005	ALL	Body	Passenger Door Module																																																												
C	2005	ALL	Body	Passenger Presence System																																																												
C	2005	ALL	Body	Base Radio																																																											
C	2005	ALL	Body	Uplevel Radio																																																											
C	2005	ALL	Body	Navigation Radio																																																											
C	2005	ALL	Body	Rear Aux. Climate Module																																																												
C	2005	ALL	Body	Rear HVAC																																																												
C	2005	ALL	Body	Rear Seat Audio																																																								V			
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																												
C	2005	ALL	Body	Vehicle Theft Deterrent																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																												
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																												
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																											
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																												
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
C	2006	ALL	Chassis	ESC																																																												
C	2006	ALL	Chassis	Tire Pressure Monitor																																																												
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2006	ALL	Chassis	VSES																																																												
C	2006	ALL	Body	Amplifier (Bose)																																																												
C	2006	ALL	Body	Body Control Module																																																												
C	2006	ALL	Body	CD Changer																																																												
C	2006	ALL	Body	Chime																																																												
C	2006	ALL	Body	Disc Player and Video Display																																																												
C	2006	ALL	Body	Driver Door Module																																																												
C	2006	ALL	Body	Driver Seat Module																																																												
C	2006	ALL	Body	Generator Battery Control Module																																																												
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																												
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
C	2006	ALL	Body	Instrument Panel Cluster																																																												
C	2006	ALL	Body	Passenger Door Module																																																												
C	2006	ALL	Body	Passenger Presence System																																																												
C	2006	ALL	Body	Base Radio																																																												
C	2006	ALL	Body	Uplevel Radio																																																												
C	2006	ALL	Body	Navigation Radio																																																												
C	2006	ALL	Body	Rear Aux. Climate Module																																																												
C	2006	ALL	Body	Rear HVAC																																																												
C	2006	ALL	Body	Rear Seat Audio																																																									V			
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2006	ALL	Body	Vehicle Theft Deterrent																																																												
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Sierra	Chassis	Electronic Suspension Control																																																												
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2007	Sierra	Body	Amplifier (Bose)																																																												
C	2007	Sierra	Body	Body Control Module																																																												
C	2007	Sierra	Body	Body Control Module (aux.)																																																												
C	2007	Sierra	Body	Digital Radio Receiver																																																												
C	2007	Sierra	Body	Driver Door Switch																																																												
C	2007	Sierra	Body	HVAC Control Module Auto																																																												
C	2007	Sierra	Body	HVAC Control Module Manual																																																												
C	2007	Sierra	Body	Instrument Panel Cluster																																																												
C	2007	Sierra	Body	Memory Seat Module																																																												
C	2007	Sierra	Body	Park Assist Module																																																												
C	2007	Sierra	Body	Passenger Door Switch																																																												
C	2007	Sierra	Body	Passenger Presence System																																																												
C	2007	Sierra	Body	Radio																																																											
C	2007	Sierra	Body	Rear Heated Seat Module																																																												
C	2007	Sierra	Body	Rear HVAC/RSA																																																												
C	2007	Sierra	Body	Rollover Sensor																																																												
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2007	Sierra	Body	Theft Deterrent Module																																																												
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Yukon	Chassis	Electronic Suspension Control																																																												
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																												
C	2007	Yukon	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2007	Yukon	Body	Assist Step Controller																																																											
C	2007	Yukon	Body	Body Control Module																																																											
C	2007	Yukon	Body	Body Control Module (aux.)																																																											
C	2007	Yukon	Body	Digital Radio Receiver																																																											
C	2007	Yukon	Body	Driver Door Switch																																																											
C	2007	Yukon	Body	HVAC Control Module Auto																																																											
C	2007	Yukon	Body	HVAC Control Module Manual																																																											
C	2007	Yukon	Body	Instrument Panel Cluster																																																											
C	2007	Yukon	Body	Lift Gate Module																																																											
C	2007	Yukon	Body	Memory Seat Module																																																											
C	2007	Yukon	Body	Park Assist Module																																																											
C	2007	Yukon	Body	Passenger Door Switch																																																											
C	2007	Yukon	Body	Passenger Presence System																																																											
C	2007	Yukon	Body	Radio																																																											
C	2007	Yukon	Body	Rear Heated Seat Module																																																											
C	2007	Yukon	Body	Rear HVAC/RSA																																																											
C	2007	Yukon	Body	Rollover Sensor																																																											
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																																											
C	2007	Yukon	Body	Theft Deterrent Module																																																											
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																											
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																											
C	2007	Yukon XL	Body	Amplifier (Bose)																																																											
C	2007	Yukon XL	Body	Assist Step Controller																																																											
C	2007	Yukon XL	Body	Body Control Module																																																											
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																											
C	2007	Yukon XL	Body	Digital Radio Receiver																																																											
C	2007	Yukon XL	Body	Driver Door Switch																																																											
C	2007	Yukon XL	Body	HVAC Control Module Auto																																																											
C	2007	Yukon XL	Body	HVAC Control Module Manual																																																											
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																											
C	2007	Yukon XL	Body	Lift Gate Module																																																											
C	2007	Yukon XL	Body	Memory Seat Module																																																											
C	2007	Yukon XL	Body	Park Assist Module																																																											
C	2007	Yukon XL	Body	Passenger Door Switch																																																											
C	2007	Yukon XL	Body	Passenger Presence System																																																											
C	2007	Yukon XL	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2007	Yukon XL	Body	Rear Heated Seat Module																																																											
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																											
C	2007	Yukon XL	Body	Rollover Sensor																																																											
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
C	2007	Yukon XL	Body	Theft Deterrent Module																																																											
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2008	Sierra	Chassis	Electronic Suspension Control																																																											
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																											
C	2008	Sierra	Body	Amplifier (Bose)																																																											
C	2008	Sierra	Body	Body Control Module																																																										
C	2008	Sierra	Body	Body Control Module (aux.)																																																											
C	2008	Sierra	Body	Digital Radio Receiver																																																											
C	2008	Sierra	Body	Driver Door Switch																																																											
C	2008	Sierra	Body	HVAC Control Module Auto																																																											
C	2008	Sierra	Body	HVAC Control Module Manual																																																											
C	2008	Sierra	Body	Instrument Panel Cluster																																																											
C	2008	Sierra	Body	Memory Seat Module																																																											
C	2008	Sierra	Body	Park Assist Module																																																											
C	2008	Sierra	Body	Passenger Door Switch																																																											
C	2008	Sierra	Body	Passenger Presence System																																																											
C	2008	Sierra	Body	Radio																																																											
C	2008	Sierra	Body	Rear Heated Seat Module																																																											
C	2008	Sierra	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2008	Sierra	Body	Rollover Sensor																																																									
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2008	Sierra	Body	Theft Deterrent Module																																																										
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Yukon	Chassis	Electronic Brake Control Module																																																										
C	2008	Yukon	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon	Body	Amplifier (Bose)																																																										
C	2008	Yukon	Body	Assist Step Controller																																																										
C	2008	Yukon	Body	Body Control Module																																																										
C	2008	Yukon	Body	Body Control Module (aux.)																																																										
C	2008	Yukon	Body	Digital Radio Receiver																																																										
C	2008	Yukon	Body	Driver Door Switch																																																										
C	2008	Yukon	Body	HVAC Control Module Auto																																																										
C	2008	Yukon	Body	HVAC Control Module Manual																																																										
C	2008	Yukon	Body	Instrument Panel Cluster																																																										
C	2008	Yukon	Body	Lift Gate Module																																																										
C	2008	Yukon	Body	Memory Seat Module																																																										
C	2008	Yukon	Body	Park Assist Module																																																										
C	2008	Yukon	Body	Passenger Door Switch																																																										
C	2008	Yukon	Body	Passenger Presence System																																																										
C	2008	Yukon	Body	Radio																																																										
C	2008	Yukon	Body	Rear Heated Seat Module																																																										
C	2008	Yukon	Body	Rear HVAC/RSA																																																										
C	2008	Yukon	Body	Rollover Sensor																																																										
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																																										
C	2008	Yukon	Body	Theft Deterrent Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																											
C	2008	Yukon Hybrid	Body	Body Control Module																																																												
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																												
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																												
C	2008	Yukon Hybrid	Body	HVAC Control Module																																																												
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
C	2008	Yukon Hybrid	Body	Lift Gate Module																																																												
C	2008	Yukon Hybrid	Body	Memory Seat Module																																																												
C	2008	Yukon Hybrid	Body	Park Assist Module																																																												
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																												
C	2008	Yukon Hybrid	Body	Passenger Presence System																																																												
C	2008	Yukon Hybrid	Body	Radio																																																												
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																												
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon XL	Body	Amplifier (Bose)																																																												
C	2008	Yukon XL	Body	Assist Step Controller																																																												
C	2008	Yukon XL	Body	Body Control Module																																																												
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2008	Yukon XL	Body	Digital Radio Receiver																																																												
C	2008	Yukon XL	Body	Driver Door Switch																																																												
C	2008	Yukon XL	Body	HVAC Control Module Auto																																																												
C	2008	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2008	Yukon XL	Body	Lift Gate Module																																																												
C	2008	Yukon XL	Body	Memory Seat Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2008	Yukon XL	Body	Park Assist Module																																																											
C	2008	Yukon XL	Body	Passenger Door Switch																																																												
C	2008	Yukon XL	Body	Passenger Presence System																																																												
C	2008	Yukon XL	Body	Radio																																																												
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2008	Yukon XL	Body	Rollover Sensor																																																												
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon XL	Body	Theft Deterrent Module																																																												
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual																																																												
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2009	Sierra	Chassis	Electronic Suspension Control																																																												
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2009	Sierra	Body	Amplifier (Bose)																																																												
C	2009	Sierra	Body	Body Control Module																																																												
C	2009	Sierra	Body	Body Control Module (aux.)																																																												
C	2009	Sierra	Body	Digital Radio Receiver																																																												
C	2009	Sierra	Body	Driver Door Switch																																																												
C	2009	Sierra	Body	HVAC Control Module Auto																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2009	Sierra	Body	HVAC Control Module Manual																																																											
C	2009	Sierra	Body	Instrument Panel Cluster																																																												
C	2009	Sierra	Body	Memory Seat Module																																																												
C	2009	Sierra	Body	Park Assist Module																																																												
C	2009	Sierra	Body	Passenger Door Switch																																																												
C	2009	Sierra	Body	Passenger Presence System																																																												
C	2009	Sierra	Body	Radio																																																												
C	2009	Sierra	Body	Rear Heated Seat Module																																																												
C	2009	Sierra	Body	Rear HVAC/RSA																																																												
C	2009	Sierra	Body	Rollover Sensor																																																												
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2009	Sierra	Body	Theft Deterrent Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																												
C	2009	Sierra Hybrid	Body	Body Control Module																																																												
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																												
C	2009	Sierra Hybrid	Body	Driver Door Switch																																																												
C	2009	Sierra Hybrid	Body	HVAC Control Module																																																												
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
C	2009	Sierra Hybrid	Body	Memory Seat Module																																																												
C	2009	Sierra Hybrid	Body	Park Assist Module																																																												
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																																												
C	2009	Sierra Hybrid	Body	Passenger Presence System																																																												
C	2009	Sierra Hybrid	Body	Radio																																																												
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																												
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
C	2009	Yukon	Chassis	Electronic Brake Control Module																																																													
C	2009	Yukon	Chassis	Electronic Suspension Control																																																													
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																													
C	2009	Yukon	Body	Amplifier (Bose)																																																													
C	2009	Yukon	Body	Assist Step Controller																																																													
C	2009	Yukon	Body	Body Control Module																																																													
C	2009	Yukon	Body	Body Control Module (aux.)																																																													
C	2009	Yukon	Body	Digital Radio Receiver																																																													
C	2009	Yukon	Body	Driver Door Switch																																																													
C	2009	Yukon	Body	HVAC Control Module Auto																																																													
C	2009	Yukon	Body	HVAC Control Module Manual																																																													
C	2009	Yukon	Body	Instrument Panel Cluster																																																													
C	2009	Yukon	Body	Left Side Object Detection Module																																																													
C	2009	Yukon	Body	Lift Gate Module																																																													
C	2009	Yukon	Body	Memory Seat Module																																																													
C	2009	Yukon	Body	Park Assist Module																																																													
C	2009	Yukon	Body	Passenger Door Switch																																																													
C	2009	Yukon	Body	Passenger Presence System																																																													
C	2009	Yukon	Body	Radio																																																													
C	2009	Yukon	Body	Rear Heated Seat Module																																																													
C	2009	Yukon	Body	Rear HVAC/RSA																																																													
C	2009	Yukon	Body	Right Side Object Detection Module																																																													
C	2009	Yukon	Body	Rollover Sensor																																																													
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																																													
C	2009	Yukon	Body	Theft Deterrent Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																													
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																													
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																													
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																													
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																													
C	2009	Yukon Hybrid	Body	Body Control Module																																																													

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																												
C	2009	Yukon Hybrid	Body	Driver Door Switch																																																												
C	2009	Yukon Hybrid	Body	Heated Seat Module																																																												
C	2009	Yukon Hybrid	Body	HVAC Control Module																																																												
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
C	2009	Yukon Hybrid	Body	Park Assist Module																																																												
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																																												
C	2009	Yukon Hybrid	Body	Passenger Presence System																																																												
C	2009	Yukon Hybrid	Body	Radio																																																												
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																												
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																												
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2009	Yukon XL	Body	Amplifier (Bose)																																																												
C	2009	Yukon XL	Body	Assist Step Controller																																																												
C	2009	Yukon XL	Body	Body Control Module																																																												
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2009	Yukon XL	Body	Digital Radio Receiver																																																												
C	2009	Yukon XL	Body	Driver Door Switch																																																												
C	2009	Yukon XL	Body	HVAC Control Module Auto																																																												
C	2009	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2009	Yukon XL	Body	Left Side Object Detection Module																																																												
C	2009	Yukon XL	Body	Lift Gate Module																																																												
C	2009	Yukon XL	Body	Memory Seat Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2009	Yukon XL	Body	Park Assist Module																																																											
C	2009	Yukon XL	Body	Passenger Door Switch																																																												
C	2009	Yukon XL	Body	Passenger Presence System																																																												
C	2009	Yukon XL	Body	Radio																																																												
C	2009	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2009	Yukon XL	Body	Right Side Object Detection Module																																																												
C	2009	Yukon XL	Body	Rollover Sensor																																																												
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2009	Yukon XL	Body	Theft Deterrent Module																																																												
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2010	Sierra	Chassis	Electronic Suspension Control																																																												
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra	Body	Amplifier (Bose)																																																												
C	2010	Sierra	Body	Body Control Module																																																											
C	2010	Sierra	Body	Body Control Module (aux.)																																																											
C	2010	Sierra	Body	Digital Radio Receiver																																																											
C	2010	Sierra	Body	Driver Door Switch																																																											
C	2010	Sierra	Body	HVAC Control Module Auto																																																											
C	2010	Sierra	Body	HVAC Control Module Manual																																																											
C	2010	Sierra	Body	Instrument Panel Cluster																																																											
C	2010	Sierra	Body	Memory Seat Module																																																											
C	2010	Sierra	Body	Park Assist Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2010	Sierra	Body	Passenger Door Switch																																																											
C	2010	Sierra	Body	Passenger Presence System																																																											
C	2010	Sierra	Body	Radio																																																										
C	2010	Sierra	Body	Rear Heated Seat Module																																																										
C	2010	Sierra	Body	Rear HVAC/RSA																																																										
C	2010	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2010	Sierra	Body	Theft Deterrent Module																																																										
C	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																										
C	2010	Sierra Hybrid	Body	Body Control Module																																																										
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																										
C	2010	Sierra Hybrid	Body	Driver Door Switch																																																										
C	2010	Sierra Hybrid	Body	Heated Seat Module																																																										
C	2010	Sierra Hybrid	Body	HVAC Control Module																																																										
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
C	2010	Sierra Hybrid	Body	Park Assist Module																																																										
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																																										
C	2010	Sierra Hybrid	Body	Passenger Presence System																																																										
C	2010	Sierra Hybrid	Body	Radio																																																										
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Yukon	Chassis	Electronic Brake Control Module																																																										
C	2010	Yukon	Chassis	Electronic Suspension Control																																																										
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon	Body	Amplifier (Bose)																																																										
C	2010	Yukon	Body	Assist Step Controller																																																										
C	2010	Yukon	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2010	Yukon	Body	Body Control Module (aux.)																																																													
C	2010	Yukon	Body	Digital Radio Receiver																																																													
C	2010	Yukon	Body	Driver Door Switch																																																													
C	2010	Yukon	Body	HVAC Control Module Auto																																																													
C	2010	Yukon	Body	HVAC Control Module Manual																																																													
C	2010	Yukon	Body	Instrument Panel Cluster																																																													
C	2010	Yukon	Body	Left Side Object Detection Module																																																													
C	2010	Yukon	Body	Lift Gate Module																																																													
C	2010	Yukon	Body	Memory Seat Module																																																													
C	2010	Yukon	Body	Park Assist Module																																																													
C	2010	Yukon	Body	Passenger Door Switch																																																													
C	2010	Yukon	Body	Passenger Presence System																																																													
C	2010	Yukon	Body	Radio																																																													
C	2010	Yukon	Body	Rear Heated Seat Module																																																													
C	2010	Yukon	Body	Rear HVAC/RSA																																																													
C	2010	Yukon	Body	Right Side Object Detection Module																																																													
C	2010	Yukon	Body	Supplemental Inflatable Restraint																																																													
C	2010	Yukon	Body	Theft Deterrent Module																																																													
C	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																													
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																													
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																													
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																													
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																													
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																													
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																													
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																													
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																													
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																													
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																													
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																													
C	2010	Yukon Hybrid	Body	Body Control Module																																																													
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																													
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																													
C	2010	Yukon Hybrid	Body	Driver Door Switch																																																													
C	2010	Yukon Hybrid	Body	Heated Seat Module																																																													
C	2010	Yukon Hybrid	Body	HVAC Control Module																																																													
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																													
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																													
C	2010	Yukon Hybrid	Body	Lift Gate Module																																																													
C	2010	Yukon Hybrid	Body	Park Assist Module																																																													
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																																													
C	2010	Yukon Hybrid	Body	Passenger Presence System																																																													
C	2010	Yukon Hybrid	Body	Radio																																																													
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																													
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																													
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																													
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																													
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																													

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																											
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																												
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																												
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2010	Yukon XL	Body	Amplifier (Bose)																																																												
C	2010	Yukon XL	Body	Assist Step Controller																																																												
C	2010	Yukon XL	Body	Body Control Module																																																												
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2010	Yukon XL	Body	Digital Radio Receiver																																																												
C	2010	Yukon XL	Body	Driver Door Switch																																																												
C	2010	Yukon XL	Body	HVAC Control Module Auto																																																												
C	2010	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2010	Yukon XL	Body	Left Side Object Detection Module																																																												
C	2010	Yukon XL	Body	Lift Gate Module																																																												
C	2010	Yukon XL	Body	Memory Seat Module																																																												
C	2010	Yukon XL	Body	Park Assist Module																																																												
C	2010	Yukon XL	Body	Passenger Door Switch																																																												
C	2010	Yukon XL	Body	Passenger Presence System																																																												
C	2010	Yukon XL	Body	Radio																																																												
C	2010	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2010	Yukon XL	Body	Right Side Object Detection Module																																																												
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2010	Yukon XL	Body	Theft Deterrent Module																																																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																												
D	2008	ALL	Chassis	Electronic Brake Control Module																																																												
D	2008	ALL	Body	Body Control Module																																																												
D	2008	ALL	Body	Body Control Module (aux.)																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
D	2008	ALL	Body	Headlamp Control Module																																																										
D	2008	ALL	Body	HVAC Control Module Auto																																																										
D	2008	ALL	Body	Instrument Panel Cluster																																																										
D	2008	ALL	Body	Park Assist Module																																																										
D	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
D	2008	ALL	Body	Theft Deterrent Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2009	ALL	Chassis	Electronic Brake Control Module																																																										
D	2009	ALL	Body	Body Control Module																																																										
D	2009	ALL	Body	Body Control Module (aux.)																																																										
D	2009	ALL	Body	Headlamp Control Module																																																										
D	2009	ALL	Body	HVAC Control Module Auto																																																										
D	2009	ALL	Body	Instrument Panel Cluster																																																										
D	2009	ALL	Body	Park Assist Module																																																										
D	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
D	2009	ALL	Body	Theft Deterrent Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2010	ALL	Chassis	Electronic Brake Control Module																																																										
D	2010	ALL	Body	Body Control Module																																																										
D	2010	ALL	Body	Body Control Module (aux.)																																																										
D	2010	ALL	Body	Headlamp Control Module																																																										
D	2010	ALL	Body	HVAC Control Module Auto																																																										
D	2010	ALL	Body	Instrument Panel Cluster																																																										
D	2010	ALL	Body	Park Assist Module																																																										
D	2010	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2004	Express/Savana	Chassis	VSES																																																									
G	2004	Express/Savana	Body	Body Control Module																																																									
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2004	Express/Savana	Body	OnStar																																																									
G	2004	Express/Savana	Body	Base Radio																																																									
G	2004	Express/Savana	Body	Uplevel Radio																																																									
G	2004	Express/Savana	Body	Remote Function Actuation																																																									
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2004	Express Access/Savana Pro	Chassis	VSES																																																									
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2004	Express Access/Savana Pro	Body	OnStar																																																									
G	2004	Express Access/Savana Pro	Body	Base Radio																																																									
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2005	Express/Savana	Chassis	VSES																																																										
G	2005	Express/Savana	Body	Body Control Module																																																										
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2005	Express/Savana	Body	Base Radio																																																										
G	2005	Express/Savana	Body	Uplevel Radio																																																										
G	2005	Express/Savana	Body	Remote Function Actuation																																																										
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2005	Express Access/Savana Pro	Chassis	VSES																																																										
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2005	Express Access/Savana Pro	Body	Base Radio																																																										
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2006	Express/Savana	Chassis	VSES																																																									
G	2006	Express/Savana	Body	Body Control Module																																																									
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2006	Express/Savana	Body	Passenger Presence System																																																									
G	2006	Express/Savana	Body	Base Radio																																																									
G	2006	Express/Savana	Body	Uplevel Radio																																																									
G	2006	Express/Savana	Body	Remote Function Actuation																																																									
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																									
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2006	Express Access/Savana Pro	Chassis	VSES																																																									
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2006	Express Access/Savana Pro	Body	Base Radio																																																									
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express/Savana	Body	Body Control Module																																																										
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2007	Express/Savana	Body	Passenger Presence System																																																										
G	2007	Express/Savana	Body	Base Radio																																																										
G	2007	Express/Savana	Body	Uplevel Radio																																																										
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2007	Express Access/Savana Pro	Body	Radio																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express/Savana	Body	Body Control Module																																																										
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2008	Express/Savana	Body	Passenger Presence System																																																										
G	2008	Express/Savana	Body	Radio																																																										
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express/Savana	Body	Rollover Sensor																																																										
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2008	Express/Savana	Body	Theft Deterrent Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2008	Express Access/Savana Pro	Body	Radio																																																											
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2009	Express/Savana	Body	Body Control Module																																																											
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2009	Express/Savana	Body	Passenger Presence System																																																											
G	2009	Express/Savana	Body	Radio																																																										
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express/Savana	Body	Rollover Sensor																																																										
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2009	Express/Savana	Body	Theft Deterrent Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																							
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																							
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																							
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																								
G	2009	Express Access/Savana Pro	Body	Radio																																																								

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																							
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express/Savana	Body	Body Control Module																																																												
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																												
G	2010	Express/Savana	Body	Passenger Presence System																																																												
G	2010	Express/Savana	Body	Radio																																																											
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
G	2010	Express/Savana	Body	Rollover Sensor																																																												
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
G	2010	Express/Savana	Body	Theft Deterrent Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																							
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2010	Express Access/Savana Pro	Body	Radio																																																										
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2004	Express/Savana	Chassis	VSES																																																										
H	2004	Express/Savana	Body	Body Control Module																																																										
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2004	Express/Savana	Body	OnStar																																																										
H	2004	Express/Savana	Body	Base Radio																																																										
H	2004	Express/Savana	Body	Uplevel Radio																																																										
H	2004	Express/Savana	Body	Remote Function Actuation																																																										
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2004	Express Access/Savana Pro	Chassis	VSES																																																										
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2004	Express Access/Savana Pro	Body	OnStar																																																										
H	2004	Express Access/Savana Pro	Body	Base Radio																																																										
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
H	2005	Express/Savana	Chassis	VSES																																																										
H	2005	Express/Savana	Body	Body Control Module																																																										
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
H	2005	Express/Savana	Body	Base Radio																																																										
H	2005	Express/Savana	Body	Uplevel Radio																																																										
H	2005	Express/Savana	Body	Remote Function Actuation																																																										
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
H	2005	Express Access/Savana Pro	Chassis	VSES																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
H	2005	Express Access/Savana Pro	Body	Base Radio																																																											
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																											
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																											
H	2006	Express/Savana	Chassis	VSES																																																											
H	2006	Express/Savana	Body	Body Control Module																																																											
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2006	Express/Savana	Body	Passenger Presence System																																																											
H	2006	Express/Savana	Body	Base Radio																																																											
H	2006	Express/Savana	Body	Uplevel Radio																																																											
H	2006	Express/Savana	Body	Remote Function Actuation																																																											
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																											
H	2006	Express Access/Savana Pro	Chassis	VSES																																																											
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																											
H	2006	Express Access/Savana Pro	Body	Base Radio																																																											
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																											
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2007	Express/Savana	Body	Body Control Module																																																											
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2007	Express/Savana	Body	Passenger Presence System																																																											
H	2007	Express/Savana	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2007	Express/Savana	Body	Uplevel Radio																																																											
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																											
H	2007	Express Access/Savana Pro	Body	Base Radio																																																											
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																											
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2008	Express/Savana	Body	Body Control Module																																																											
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2008	Express/Savana	Body	Passenger Presence System																																																											
H	2008	Express/Savana	Body	Radio																																																											
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
H	2008	Express/Savana	Body	Rollover Sensor																																																											
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2008	Express/Savana	Body	Theft Deterrent Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module																																																										
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																																										
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express/Savana	Body	Theft Deterrent Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express/Savana	Body	Body Control Module																																																										
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2010	Express/Savana	Body	Passenger Presence System																																																										
H	2010	Express/Savana	Body	Radio																																																										
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express/Savana	Body	Rollover Sensor																																																										
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express/Savana	Body	Theft Deterrent Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2010	Express Access/Savana Pro	Body	Radio																																																										
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
K	2004	ALL	Chassis	ESC																																																											
K	2004	ALL	Chassis	Rear Wheel Steering																																																												
K	2004	ALL	Chassis	Tire Pressure Monitor																																																												
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																												
K	2004	ALL	Chassis	VSES																																																											
K	2004	ALL	Body	Amplifier (Bose)																																																												
K	2004	ALL	Body	Body Control Module																																																											
K	2004	ALL	Body	CD Changer																																																											
K	2004	ALL	Body	Chime																																																											
K	2004	ALL	Body	Driver Door Module																																																											
K	2004	ALL	Body	Driver Seat Module																																																											
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2004	ALL	Body	Instrument Panel Cluster																																																											
K	2004	ALL	Body	OnStar																																																										
K	2004	ALL	Body	Passenger Door Module																																																											
K	2004	ALL	Body	Passenger Presence System																																																											
K	2004	ALL	Body	Radio Base																																																											
K	2004	ALL	Body	Radio Uplevel																																																											
K	2004	ALL	Body	Radio Navigation																																																											
K	2004	ALL	Body	Rear Aux. Climate Module																																																											
K	2004	ALL	Body	Rear HVAC																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2004	ALL	Body	Rear Seat Audio																																																					V				
K	2004	ALL	Body	Rear Seat Entertainment																																																									
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
K	2004	ALL	Body	Vehicle Theft Deterrent																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																																																										
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																																																										
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2005	ALL	Body	Instrument Panel Cluster																																																										
K	2005	ALL	Body	Passenger Door Module																																																										
K	2005	ALL	Body	Passenger Presence System																																																										
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																																																										
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																									V	
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2005	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																												
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																												
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																												
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																												
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
K	2006	ALL	Chassis	ESC																																																											
K	2006	ALL	Chassis	Tire Pressure Monitor																																																											
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																											
K	2006	ALL	Chassis	VSES																																																										
K	2006	ALL	Body	Amplifier (Bose)																																																											
K	2006	ALL	Body	Body Control Module																																																										
K	2006	ALL	Body	CD Changer																																																										
K	2006	ALL	Body	Chime																																																										
K	2006	ALL	Body	Disc Player and Video Display																																																											
K	2006	ALL	Body	Driver Door Module																																																										
K	2006	ALL	Body	Driver Seat Module																																																											
K	2006	ALL	Body	Generator Battery Control Module																																																											
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																									
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
K	2006	ALL	Body	Instrument Panel Cluster																																																										
K	2006	ALL	Body	Passenger Door Module																																																										
K	2006	ALL	Body	Passenger Presence System																																																										
K	2006	ALL	Body	Base Radio																																																										
K	2006	ALL	Body	Uplevel Radio																																																										
K	2006	ALL	Body	Navigation Radio																																																										
K	2006	ALL	Body	Rear Aux. Climate Module																																																										
K	2006	ALL	Body	Rear HVAC																																																										
K	2006	ALL	Body	Rear Seat Audio																																																							V			
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2006	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																											
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																											
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2007	Sierra	Chassis	Electronic Suspension Control																																																											
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																											
K	2007	Sierra	Body	Amplifier (Bose)																																																											
K	2007	Sierra	Body	Body Control Module																																																										
K	2007	Sierra	Body	Body Control Module (aux.)																																																										
K	2007	Sierra	Body	Digital Radio Receiver																																																										
K	2007	Sierra	Body	Driver Door Switch																																																										
K	2007	Sierra	Body	HVAC Control Module Auto																																																										
K	2007	Sierra	Body	HVAC Control Module Manual																																																										
K	2007	Sierra	Body	Instrument Panel Cluster																																																										
K	2007	Sierra	Body	Memory Seat Module																																																										
K	2007	Sierra	Body	Park Assist Module																																																										
K	2007	Sierra	Body	Passenger Door Switch																																																										
K	2007	Sierra	Body	Passenger Presence System																																																										
K	2007	Sierra	Body	Radio																																																										
K	2007	Sierra	Body	Rear Heated Seat Module																																																										
K	2007	Sierra	Body	Rear HVAC/RSA																																																										
K	2007	Sierra	Body	Rollover Sensor																																																										
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2007	Sierra	Body	Theft Deterrent Module																																																										
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Yukon	Chassis	Electronic Suspension Control																																																										
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																										
K	2007	Yukon	Body	Amplifier (Bose)																																																										
K	2007	Yukon	Body	Assist Step Controller																																																										
K	2007	Yukon	Body	Body Control Module																																																										
K	2007	Yukon	Body	Body Control Module (aux.)																																																										
K	2007	Yukon	Body	Digital Radio Receiver																																																										
K	2007	Yukon	Body	Driver Door Switch																																																										
K	2007	Yukon	Body	HVAC Control Module Auto																																																										
K	2007	Yukon	Body	HVAC Control Module Manual																																																										
K	2007	Yukon	Body	Instrument Panel Cluster																																																										
K	2007	Yukon	Body	Lift Gate Module																																																										
K	2007	Yukon	Body	Memory Seat Module																																																										
K	2007	Yukon	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2007	Yukon	Body	Passenger Door Switch																																																											
K	2007	Yukon	Body	Passenger Presence System																																																											
K	2007	Yukon	Body	Radio																																																										
K	2007	Yukon	Body	Rear Heated Seat Module																																																										
K	2007	Yukon	Body	Rear HVAC/RSA																																																										
K	2007	Yukon	Body	Rollover Sensor																																																										
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																																										
K	2007	Yukon	Body	Theft Deterrent Module																																																										
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2007	Yukon XL	Body	Amplifier (Bose)																																																										
K	2007	Yukon XL	Body	Assist Step Controller																																																										
K	2007	Yukon XL	Body	Body Control Module																																																										
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2007	Yukon XL	Body	Digital Radio Receiver																																																										
K	2007	Yukon XL	Body	Driver Door Switch																																																										
K	2007	Yukon XL	Body	HVAC Control Module Auto																																																										
K	2007	Yukon XL	Body	HVAC Control Module Manual																																																										
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2007	Yukon XL	Body	Lift Gate Module																																																										
K	2007	Yukon XL	Body	Memory Seat Module																																																										
K	2007	Yukon XL	Body	Park Assist Module																																																										
K	2007	Yukon XL	Body	Passenger Door Switch																																																										
K	2007	Yukon XL	Body	Passenger Presence System																																																										
K	2007	Yukon XL	Body	Radio																																																									
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2007	Yukon XL	Body	Rollover Sensor																																																										
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2007	Yukon XL	Body	Theft Deterrent Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2008	Sierra	Chassis	Electronic Suspension Control																																																												
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																												
K	2008	Sierra	Body	Amplifier (Bose)																																																												
K	2008	Sierra	Body	Body Control Module																																																											
K	2008	Sierra	Body	Body Control Module (aux.)																																																											
K	2008	Sierra	Body	Digital Radio Receiver																																																											
K	2008	Sierra	Body	Driver Door Switch																																																											
K	2008	Sierra	Body	HVAC Control Module Auto																																																											
K	2008	Sierra	Body	HVAC Control Module Manual																																																											
K	2008	Sierra	Body	Instrument Panel Cluster																																																											
K	2008	Sierra	Body	Memory Seat Module																																																											
K	2008	Sierra	Body	Park Assist Module																																																											
K	2008	Sierra	Body	Passenger Door Switch																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2008	Sierra	Body	Passenger Presence System																																																										
K	2008	Sierra	Body	Radio																																																										
K	2008	Sierra	Body	Rear Heated Seat Module																																																										
K	2008	Sierra	Body	Rear HVAC/RSA																																																										
K	2008	Sierra	Body	Rollover Sensor																																																										
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																										
K	2008	Sierra	Body	Theft Deterrent Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Yukon	Chassis	Electronic Brake Control Module																																																										
K	2008	Yukon	Chassis	Electronic Suspension Control																																																										
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																										
K	2008	Yukon	Body	Amplifier (Bose)																																																										
K	2008	Yukon	Body	Assist Step Controller																																																										
K	2008	Yukon	Body	Body Control Module																																																										
K	2008	Yukon	Body	Body Control Module (aux.)																																																										
K	2008	Yukon	Body	Digital Radio Receiver																																																										
K	2008	Yukon	Body	Driver Door Switch																																																										
K	2008	Yukon	Body	HVAC Control Module Auto																																																										
K	2008	Yukon	Body	HVAC Control Module Manual																																																										
K	2008	Yukon	Body	Instrument Panel Cluster																																																										
K	2008	Yukon	Body	Lift Gate Module																																																										
K	2008	Yukon	Body	Memory Seat Module																																																										
K	2008	Yukon	Body	Park Assist Module																																																										
K	2008	Yukon	Body	Passenger Door Switch																																																										
K	2008	Yukon	Body	Passenger Presence System																																																										
K	2008	Yukon	Body	Radio																																																										
K	2008	Yukon	Body	Rear Heated Seat Module																																																										
K	2008	Yukon	Body	Rear HVAC/RSA																																																										
K	2008	Yukon	Body	Rollover Sensor																																																										
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																																										
K	2008	Yukon	Body	Theft Deterrent Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																										
K	2008	Yukon Hybrid	Body	Body Control Module																																																										
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																										
K	2008	Yukon Hybrid	Body	Driver Door Switch																																																										
K	2008	Yukon Hybrid	Body	HVAC Control Module																																																										
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
K	2008	Yukon Hybrid	Body	Lift Gate Module																																																										
K	2008	Yukon Hybrid	Body	Memory Seat Module																																																										
K	2008	Yukon Hybrid	Body	Park Assist Module																																																										
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																																										
K	2008	Yukon Hybrid	Body	Passenger Presence System																																																										
K	2008	Yukon Hybrid	Body	Radio																																																										
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																										
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																										
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2008	Yukon XL	Body	Amplifier (Bose)																																																										
K	2008	Yukon XL	Body	Assist Step Controller																																																										
K	2008	Yukon XL	Body	Body Control Module																																																										
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2008	Yukon XL	Body	Digital Radio Receiver																																																										
K	2008	Yukon XL	Body	Driver Door Switch																																																										
K	2008	Yukon XL	Body	HVAC Control Module Auto																																																										
K	2008	Yukon XL	Body	HVAC Control Module Manual																																																										
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2008	Yukon XL	Body	Lift Gate Module																																																										
K	2008	Yukon XL	Body	Memory Seat Module																																																										
K	2008	Yukon XL	Body	Park Assist Module																																																										
K	2008	Yukon XL	Body	Passenger Door Switch																																																										
K	2008	Yukon XL	Body	Passenger Presence System																																																										
K	2008	Yukon XL	Body	Radio																																																										
K	2008	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2008	Yukon XL	Body	Rollover Sensor																																																										
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2008	Yukon XL	Body	Theft Deterrent Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2009	Sierra	Chassis	Electronic Suspension Control																																																										
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2009	Sierra	Body	Amplifier (Bose)																																																										
K	2009	Sierra	Body	Body Control Module																																																										
K	2009	Sierra	Body	Body Control Module (aux.)																																																										
K	2009	Sierra	Body	Digital Radio Receiver																																																										
K	2009	Sierra	Body	Driver Door Switch																																																										
K	2009	Sierra	Body	HVAC Control Module Auto																																																										
K	2009	Sierra	Body	HVAC Control Module Manual																																																										
K	2009	Sierra	Body	Instrument Panel Cluster																																																										
K	2009	Sierra	Body	Memory Seat Module																																																										
K	2009	Sierra	Body	Park Assist Module																																																										
K	2009	Sierra	Body	Passenger Door Switch																																																										
K	2009	Sierra	Body	Passenger Presence System																																																										
K	2009	Sierra	Body	Radio																																																										
K	2009	Sierra	Body	Rear Heated Seat Module																																																										
K	2009	Sierra	Body	Rear HVAC/RSA																																																										
K	2009	Sierra	Body	Rollover Sensor																																																										
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2009	Sierra	Body	Theft Deterrent Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Sierra Hybrid	Body	Body Control Module																																																										
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Sierra Hybrid	Body	Driver Door Switch																																																										
K	2009	Sierra Hybrid	Body	HVAC Control Module																																																										
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Sierra Hybrid	Body	Memory Seat Module																																																										
K	2009	Sierra Hybrid	Body	Park Assist Module																																																										
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																																										
K	2009	Sierra Hybrid	Body	Passenger Presence System																																																										
K	2009	Sierra Hybrid	Body	Radio																																																										
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Sierra Hybrid	Body	Rollover Sensor																																																										
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Yukon	Chassis	Electronic Brake Control Module																																																										
K	2009	Yukon	Chassis	Electronic Suspension Control																																																										
K	2009	Yukon	Chassis	Trailer Brake Control Module																																																										
K	2009	Yukon	Body	Amplifier (Bose)																																																										
K	2009	Yukon	Body	Assist Step Controller																																																										
K	2009	Yukon	Body	Body Control Module																																																										
K	2009	Yukon	Body	Body Control Module (aux.)																																																										
K	2009	Yukon	Body	Digital Radio Receiver																																																										
K	2009	Yukon	Body	Driver Door Switch																																																										
K	2009	Yukon	Body	HVAC Control Module Auto																																																										
K	2009	Yukon	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2009	Yukon	Body	Instrument Panel Cluster																																																										
K	2009	Yukon	Body	Left Side Object Detection Module																																																										
K	2009	Yukon	Body	Lift Gate Module																																																										
K	2009	Yukon	Body	Memory Seat Module																																																										
K	2009	Yukon	Body	Park Assist Module																																																										
K	2009	Yukon	Body	Passenger Door Switch																																																										
K	2009	Yukon	Body	Passenger Presence System																																																										
K	2009	Yukon	Body	Radio																																																										
K	2009	Yukon	Body	Rear Heated Seat Module																																																										
K	2009	Yukon	Body	Rear HVAC/RSA																																																										
K	2009	Yukon	Body	Right Side Object Detection Module																																																										
K	2009	Yukon	Body	Rollover Sensor																																																										
K	2009	Yukon	Body	Supplemental Inflatable Restraint																																																										
K	2009	Yukon	Body	Theft Deterrent Module																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																										
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																										
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Yukon Hybrid	Body	Body Control Module																																																										
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Yukon Hybrid	Body	Driver Door Switch																																																										
K	2009	Yukon Hybrid	Body	Heated Seat Module																																																										
K	2009	Yukon Hybrid	Body	HVAC Control Module																																																										
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
K	2009	Yukon Hybrid	Body	Park Assist Module																																																										
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																																										
K	2009	Yukon Hybrid	Body	Passenger Presence System																																																										
K	2009	Yukon Hybrid	Body	Radio																																																										
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
K	2009	Yukon Hybrid	Body	Rollover Sensor																																																										
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																												
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																												
K	2009	Yukon XL	Body	Amplifier (Bose)																																																												
K	2009	Yukon XL	Body	Assist Step Controller																																																												
K	2009	Yukon XL	Body	Body Control Module																																																												
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																												
K	2009	Yukon XL	Body	Digital Radio Receiver																																																												
K	2009	Yukon XL	Body	Driver Door Switch																																																												
K	2009	Yukon XL	Body	HVAC Control Module Auto																																																												
K	2009	Yukon XL	Body	HVAC Control Module Manual																																																												
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																												
K	2009	Yukon XL	Body	Left Side Object Detection Module																																																												
K	2009	Yukon XL	Body	Lift Gate Module																																																												
K	2009	Yukon XL	Body	Memory Seat Module																																																												
K	2009	Yukon XL	Body	Park Assist Module																																																												
K	2009	Yukon XL	Body	Passenger Door Switch																																																												
K	2009	Yukon XL	Body	Passenger Presence System																																																												
K	2009	Yukon XL	Body	Radio																																																												
K	2009	Yukon XL	Body	Rear Heated Seat Module																																																												
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																												
K	2009	Yukon XL	Body	Right Side Object Detection Module																																																												
K	2009	Yukon XL	Body	Rollover Sensor																																																												
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
K	2009	Yukon XL	Body	Theft Deterrent Module																																																												
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																												
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2010	Sierra	Chassis	Electronic Suspension Control																																																												
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																												
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra	Body	Amplifier (Bose)																																																												
K	2010	Sierra	Body	Body Control Module																																																											
K	2010	Sierra	Body	Body Control Module (aux.)																																																											
K	2010	Sierra	Body	Digital Radio Receiver																																																											
K	2010	Sierra	Body	Driver Door Switch																																																											
K	2010	Sierra	Body	HVAC Control Module Auto																																																											
K	2010	Sierra	Body	HVAC Control Module Manual																																																											
K	2010	Sierra	Body	Instrument Panel Cluster																																																											
K	2010	Sierra	Body	Memory Seat Module																																																											
K	2010	Sierra	Body	Park Assist Module																																																											
K	2010	Sierra	Body	Passenger Door Switch																																																											
K	2010	Sierra	Body	Passenger Presence System																																																											
K	2010	Sierra	Body	Radio																																																											
K	2010	Sierra	Body	Rear Heated Seat Module																																																											
K	2010	Sierra	Body	Rear HVAC/RSA																																																											
K	2010	Sierra	Body	Supplemental Inflatable Restraint																																																											
K	2010	Sierra	Body	Theft Deterrent Module																																																											
K	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																											
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																											
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																											
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Sierra Hybrid	Body	Body Control Module																																																										
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Sierra Hybrid	Body	Driver Door Switch																																																										
K	2010	Sierra Hybrid	Body	Heated Seat Module																																																										
K	2010	Sierra Hybrid	Body	HVAC Control Module																																																										
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Sierra Hybrid	Body	Park Assist Module																																																										
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																																										
K	2010	Sierra Hybrid	Body	Passenger Presence System																																																										
K	2010	Sierra Hybrid	Body	Radio																																																										
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon	Chassis	Electronic Brake Control Module																																																										
K	2010	Yukon	Chassis	Electronic Suspension Control																																																										
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon	Body	Amplifier (Bose)																																																										
K	2010	Yukon	Body	Assist Step Controller																																																										
K	2010	Yukon	Body	Body Control Module																																																										
K	2010	Yukon	Body	Body Control Module (aux.)																																																										
K	2010	Yukon	Body	Digital Radio Receiver																																																										
K	2010	Yukon	Body	Driver Door Switch																																																										
K	2010	Yukon	Body	HVAC Control Module Auto																																																										
K	2010	Yukon	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2010	Yukon	Body	Instrument Panel Cluster																																																											
K	2010	Yukon	Body	Left Side Object Detection Module																																																												
K	2010	Yukon	Body	Lift Gate Module																																																												
K	2010	Yukon	Body	Memory Seat Module																																																												
K	2010	Yukon	Body	Park Assist Module																																																												
K	2010	Yukon	Body	Passenger Door Switch																																																												
K	2010	Yukon	Body	Passenger Presence System																																																												
K	2010	Yukon	Body	Radio																																																												
K	2010	Yukon	Body	Rear Heated Seat Module																																																												
K	2010	Yukon	Body	Rear HVAC/RSA																																																												
K	2010	Yukon	Body	Right Side Object Detection Module																																																												
K	2010	Yukon	Body	Supplemental Inflatable Restraint																																																												
K	2010	Yukon	Body	Theft Deterrent Module																																																												
K	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																												
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																												
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																												
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																												
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Yukon Hybrid	Body	Body Control Module																																																												
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																												
K	2010	Yukon Hybrid	Body	Driver Door Switch																																																												
K	2010	Yukon Hybrid	Body	Heated Seat Module																																																												
K	2010	Yukon Hybrid	Body	HVAC Control Module																																																												
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
K	2010	Yukon Hybrid	Body	Lift Gate Module																																																												
K	2010	Yukon Hybrid	Body	Park Assist Module																																																												
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																																												
K	2010	Yukon Hybrid	Body	Passenger Presence System																																																												
K	2010	Yukon Hybrid	Body	Radio																																																												
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																												
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																												
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																												
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																												
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																												
K	2010	Yukon XL	Body	Amplifier (Bose)																																																												
K	2010	Yukon XL	Body	Assist Step Controller																																																												
K	2010	Yukon XL	Body	Body Control Module																																																												
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																												
K	2010	Yukon XL	Body	Digital Radio Receiver																																																												
K	2010	Yukon XL	Body	Driver Door Switch																																																												
K	2010	Yukon XL	Body	HVAC Control Module Auto																																																												
K	2010	Yukon XL	Body	HVAC Control Module Manual																																																												
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																												
K	2010	Yukon XL	Body	Left Side Object Detection Module																																																												
K	2010	Yukon XL	Body	Lift Gate Module																																																												
K	2010	Yukon XL	Body	Memory Seat Module																																																												
K	2010	Yukon XL	Body	Park Assist Module																																																												
K	2010	Yukon XL	Body	Passenger Door Switch																																																												
K	2010	Yukon XL	Body	Passenger Presence System																																																												
K	2010	Yukon XL	Body	Radio																																																												
K	2010	Yukon XL	Body	Rear Heated Seat Module																																																												
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																												
K	2010	Yukon XL	Body	Right Side Object Detection Module																																																												
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
K	2010	Yukon XL	Body	Theft Deterrent Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
L	2004	ALL	Chassis	4WAL 3 Sensor																																																												
L	2004	ALL	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2004	ALL	Body	Instrument Panel Cluster																																																										
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2005	ALL	Chassis	4WAL 3 Sensor																																																										
L	2005	ALL	Body	Body Control Module																																																										
L	2005	ALL	Body	Instrument Panel Cluster																																																										
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																										
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																										
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																										
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																										
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																										
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2010	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2010	Terrain	Body	Body Control Module																																																										
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2010	Terrain	Body	Passenger Presence Module																																																										
L	2010	Terrain	Body	Instrument Cluster																																																										
L	2010	Terrain	Body	Radio																																																										
L	2010	Terrain	Body	Multimedia Player Interface Module																																																										
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																																										
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2010	Terrain	Body	Liftgate Control Module																																																										
L	2010	Terrain	Body	Parking Assist Control Module																																																										
L	2010	Terrain	Body	Frontview Camera Module																																																										
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																																										
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																																										
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																										
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																										
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2011	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2011	Terrain	Body	Body Control Module																																																										
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2011	Terrain	Body	Passenger Presence Module																																																										
L	2011	Terrain	Body	Instrument Cluster																																																										
L	2011	Terrain	Body	Radio																																																										
L	2011	Terrain	Body	Multimedia Player Interface Module																																																										
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2011	Terrain	Body	Liftgate Control Module																																																												
L	2011	Terrain	Body	Parking Assist Control Module																																																												
L	2011	Terrain	Body	Frontview Camera Module																																																												
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																												
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2012	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2012	Terrain	Body	Body Control Module																																																												
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2012	Terrain	Body	Passenger Presence Module																																																												
L	2012	Terrain	Body	Instrument Cluster																																																												
L	2012	Terrain	Body	Radio																																																											
L	2012	Terrain	Body	Multimedia Player Interface Module																																																											
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2012	Terrain	Body	Liftgate Control Module																																																											
L	2012	Terrain	Body	Parking Assist Control Module																																																											
L	2012	Terrain	Body	Frontview Camera Module																																																											
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																																											
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2013	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2013	Terrain	Chassis	Power Steering Control Module																																																											
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																																											
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2013	Terrain	Body	Passenger Presence Module																																																											
L	2013	Terrain	Body	Instrument Cluster																																																											
L	2013	Terrain	Body	Radio																																																											
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2013	Terrain	Body	Liftgate Control Module																																																											
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2013	Terrain	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2013	Terrain	Body	Frontview Camera Module																																																											
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2014	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2014	Terrain	Chassis	Power Steering Control Module																																																											
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																																											
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2014	Terrain	Body	Passenger Presence Module																																																											
L	2014	Terrain	Body	Instrument Cluster																																																											
L	2014	Terrain	Body	Radio																																																											
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2014	Terrain	Body	Liftgate Control Module																																																											
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2014	Terrain	Body	Parking Assist Control Module																																																											
L	2014	Terrain	Body	Frontview Camera Module																																																											
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2015	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2015	Terrain	Chassis	Power Steering Control Module																																																											
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																																											
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2015	Terrain	Body	Passenger Presence Module																																																											
L	2015	Terrain	Body	Instrument Cluster																																																											
L	2015	Terrain	Body	Radio																																																											
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																																											
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2015	Terrain	Body	Liftgate Control Module																																																											
L	2015	Terrain	Body	Seat Memory Control Module																																																											
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2015	Terrain	Body	Parking Assist Control Module																																																											
L	2015	Terrain	Body	Frontview Camera Module																																																											
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																											
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2016	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2016	Terrain	Chassis	Power Steering Control Module																																																											
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																																											
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2016	Terrain	Body	Passenger Presence Module																																																											
L	2016	Terrain	Body	Instrument Cluster																																																											
L	2016	Terrain	Body	Radio																																																											
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																																											
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2016	Terrain	Body	Liftgate Control Module																																																											
L	2016	Terrain	Body	Seat Memory Control Module																																																											
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2016	Terrain	Body	Parking Assist Control Module																																																											
L	2016	Terrain	Body	Frontview Camera Module																																																											
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
M	2004	ALL	Chassis	4WAL 3 Sensor																																																											
M	2004	ALL	Body	Body Control Module																																																											
M	2004	ALL	Body	Instrument Panel Cluster																																																											
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																											
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
M	2005	ALL	Chassis	4WAL 3 Sensor																																																											
M	2005	ALL	Body	Body Control Module																																																											
M	2005	ALL	Body	Instrument Panel Cluster																																																											
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																											
P	2007	ALL	Body	Theft Deterrent Module																																																											
R	2007	ALL	Powertrain	Engine Control Module																																																											
R	2007	ALL	Powertrain	Transmission Control Module																																																											
R	2007	ALL	Chassis	Electronic Brake Control Module																																																											
R	2007	ALL	Body	Body Control Module																																																											
R	2007	ALL	Body	Digital Radio Receiver																																																											
R	2007	ALL	Body	Driver Door Switch																																																											
R	2007	ALL	Body	Head Up Display																																																											
R	2007	ALL	Body	Heated Seat Module																																																											
R	2007	ALL	Body	HVAC Control Module Auto																																																											
R	2007	ALL	Body	HVAC Control Module Manual																																																											
R	2007	ALL	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2007	ALL	Body	Lift Gate Module																																																												
R	2007	ALL	Body	Park Assist Module																																																												
R	2007	ALL	Body	Passenger Door Switch																																																												
R	2007	ALL	Body	Passenger Presence System																																																												
R	2007	ALL	Body	Radio																																																												
R	2007	ALL	Body	Rear HVAC/RSA																																																												
R	2007	ALL	Body	Rollover Sensor																																																												
R	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2007	ALL	Body	Theft Deterrent Module																																																												
R	2008	ALL	Powertrain	Engine Control Module																																																												
R	2008	ALL	Powertrain	Transmission Control Module																																																												
R	2008	ALL	Chassis	Electronic Brake Control Module																																																												
R	2008	ALL	Body	Body Control Module																																																												
R	2008	ALL	Body	Digital Radio Receiver																																																												
R	2008	ALL	Body	Driver Door Switch																																																												
R	2008	ALL	Body	Head Up Display																																																												
R	2008	ALL	Body	Heated Seat Module																																																												
R	2008	ALL	Body	HVAC Control Module Auto																																																												
R	2008	ALL	Body	HVAC Control Module Manual																																																												
R	2008	ALL	Body	Instrument Panel Cluster																																																												
R	2008	ALL	Body	Lift Gate Module																																																												
R	2008	ALL	Body	Park Assist Module																																																												
R	2008	ALL	Body	Passenger Door Switch																																																												
R	2008	ALL	Body	Passenger Presence System																																																												
R	2008	ALL	Body	Radio																																																												
R	2008	ALL	Body	Rear HVAC/RSA																																																												
R	2008	ALL	Body	Rollover Sensor																																																												
R	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2008	ALL	Body	Theft Deterrent Module																																																												
R	2009	ALL	Powertrain	Engine Control Module																																																												
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2009	ALL	Powertrain	Transmission Control Module																																																												
R	2009	ALL	Chassis	Electronic Brake Control Module																																																												
R	2009	ALL	Body	Body Control Module																																																												
R	2009	ALL	Body	Digital Radio Receiver																																																												
R	2009	ALL	Body	Driver Door Switch																																																												
R	2009	ALL	Body	Head Up Display																																																												
R	2009	ALL	Body	Heated Seat Module																																																												
R	2009	ALL	Body	HVAC Control Module Auto																																																												
R	2009	ALL	Body	HVAC Control Module Manual																																																												
R	2009	ALL	Body	Instrument Panel Cluster																																																												
R	2009	ALL	Body	Lift Gate Module																																																												
R	2009	ALL	Body	Park Assist Module																																																												
R	2009	ALL	Body	Passenger Door Switch																																																												
R	2009	ALL	Body	Passenger Presence System																																																												
R	2009	ALL	Body	Radio																																																												
R	2009	ALL	Body	Rear HVAC/RSA																																																												
R	2009	ALL	Body	Rollover Sensor																																																												
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2009	ALL	Body	Theft Deterrent Module																																																												
R	2010	ALL	Powertrain	Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2010	ALL	Powertrain	Transmission Control Module																																																												
R	2010	ALL	Chassis	Electronic Brake Control Module																																																												
R	2010	ALL	Body	Body Control Module																																																											
R	2010	ALL	Body	Digital Radio Receiver																																																											
R	2010	ALL	Body	Driver Door Switch																																																											
R	2010	ALL	Body	Head Up Display																																																											
R	2010	ALL	Body	Heated Seat Module																																																											
R	2010	ALL	Body	HVAC Control Module Auto																																																											
R	2010	ALL	Body	HVAC Control Module Manual																																																											
R	2010	ALL	Body	Instrument Panel Cluster																																																											
R	2010	ALL	Body	Lift Gate Module																																																											
R	2010	ALL	Body	Park Assist Module																																																											
R	2010	ALL	Body	Passenger Door Switch																																																											
R	2010	ALL	Body	Passenger Presence System																																																											
R	2010	ALL	Body	Radio																																																											
R	2010	ALL	Body	Rear HVAC/RSA																																																											
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2010	ALL	Body	Theft Deterrent Module																																																											
R	2011	ALL	Powertrain	Engine Control Module																																																											
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2011	ALL	Powertrain	Transmission Control Module																																																											
R	2011	ALL	Chassis	Electronic Brake Control Module																																																											
R	2011	ALL	Body	Body Control Module																																																											
R	2011	ALL	Body	Digital Radio Receiver																																																											
R	2011	ALL	Body	Driver Door Switch																																																											
R	2011	ALL	Body	Head Up Display																																																											
R	2011	ALL	Body	Heated Seat Module																																																											
R	2011	ALL	Body	HVAC Control Module Auto																																																											
R	2011	ALL	Body	HVAC Control Module Manual																																																											
R	2011	ALL	Body	Instrument Panel Cluster																																																											
R	2011	ALL	Body	Lift Gate Module																																																											
R	2011	ALL	Body	Park Assist Module																																																											
R	2011	ALL	Body	Passenger Door Switch																																																											
R	2011	ALL	Body	Passenger Presence System																																																											
R	2011	ALL	Body	Radio																																																											
R	2011	ALL	Body	Rear HVAC/RSA																																																											
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2011	ALL	Body	Theft Deterrent Module																																																											
R	2012	ALL	Powertrain	Engine Control Module																																																											
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2012	ALL	Powertrain	Transmission Control Module																																																											
R	2012	ALL	Chassis	Electronic Brake Control Module																																																											
R	2012	ALL	Body	Body Control Module																																																											
R	2012	ALL	Body	Digital Radio Receiver																																																											
R	2012	ALL	Body	Driver Door Switch																																																											
R	2012	ALL	Body	Head Up Display																																																											
R	2012	ALL	Body	Heated Seat Module																																																											
R	2012	ALL	Body	HVAC Control Module Auto																																																											
R	2012	ALL	Body	HVAC Control Module Manual																																																											
R	2012	ALL	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2012	ALL	Body	Lift Gate Module																																																											
R	2012	ALL	Body	Park Assist Module																																																											
R	2012	ALL	Body	Passenger Door Switch																																																											
R	2012	ALL	Body	Passenger Presence System																																																											
R	2012	ALL	Body	Radio																																																											
R	2012	ALL	Body	Rear HVAC/RSA																																																												
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2012	ALL	Body	Theft Deterrent Module																																																												
R	2013	ALL	Powertrain	Engine Control Module																																																												
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2013	ALL	Powertrain	Transmission Control Module																																																												
R	2013	ALL	Chassis	Electronic Brake Control Module																																																												
R	2013	ALL	Body	Body Control Module																																																												
R	2013	ALL	Body	Digital Radio Receiver																																																												
R	2013	ALL	Body	Driver Door Switch																																																												
R	2013	ALL	Body	Head Up Display																																																												
R	2013	ALL	Body	Heated Seat Module																																																												
R	2013	ALL	Body	HVAC Control Module Auto																																																												
R	2013	ALL	Body	HVAC Control Module Manual																																																												
R	2013	ALL	Body	Instrument Panel Cluster																																																												
R	2013	ALL	Body	Left Side Object Detection Module																																																												
R	2013	ALL	Body	Lift Gate Module																																																												
R	2013	ALL	Body	Park Assist Module																																																												
R	2013	ALL	Body	Passenger Door Switch																																																												
R	2013	ALL	Body	Passenger Presence System																																																												
R	2013	ALL	Body	Radio																																																											
R	2013	ALL	Body	Rear HVAC/RSA																																																												
R	2013	ALL	Body	Right Side Object Detection Module																																																												
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2013	ALL	Body	Theft Deterrent Module																																																												
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2014	Acadia	Powertrain	Chassis Control Module																																																												
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
R	2014	Acadia	Chassis	Electronic Brake Control Module																																																												
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Acadia	Body	Passenger Presence Module																																																												
R	2014	Acadia	Body	Instrument Cluster																																																												
R	2014	Acadia	Body	Head-Up Display Module																																																												
R	2014	Acadia	Body	Radio																																																											
R	2014	Acadia	Body	Rear Audio Control Module																																																												
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																												
R	2014	Acadia	Body	Personal Audio Link Control Module																																																												
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																										V																	
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																										V																	
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																											
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2014	Acadia	Body	Liftgate Control Module																																																											
R	2014	Acadia	Body	Seat Memory Control Module																																																												
R	2014	Acadia	Body	Front Seat Heating Control Module																																																												
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																												
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																												
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																												
R	2014	Acadia	Body	Parking Assist Control Module																																																												
R	2014	Acadia	Body	Frontview Camera Module																																																												
R	2014	Acadia	Body	Theft Deterrent Module																																																												
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
R	2015	Acadia	Chassis	Electronic Brake Control Module																																																												
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Acadia	Body	Passenger Presence Module																																																												
R	2015	Acadia	Body	Instrument Cluster																																																												
R	2015	Acadia	Body	Head-Up Display Module																																																												
R	2015	Acadia	Body	Radio																																																												
R	2015	Acadia	Body	Rear Audio Control Module																																																												
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																												
R	2015	Acadia	Body	Personal Audio Link Control Module																																																												
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																									V																		
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																									V																		
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																											
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																												
R	2015	Acadia	Body	Liftgate Control Module																																																												
R	2015	Acadia	Body	Seat Memory Control Module																																																												
R	2015	Acadia	Body	Front Seat Heating Control Module																																																												
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																												
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																												
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																												
R	2015	Acadia	Body	Parking Assist Control Module																																																												
R	2015	Acadia	Body	Frontview Camera Module																																																												
R	2015	Acadia	Body	Theft Deterrent Module																																																												
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
R	2016	Acadia	Chassis	Electronic Brake Control Module																																																												
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2016	Acadia	Body	Passenger Presence Module																																																												
R	2016	Acadia	Body	Instrument Cluster																																																												
R	2016	Acadia	Body	Head-Up Display Module																																																												
R	2016	Acadia	Body	Radio																																																											
R	2016	Acadia	Body	Rear Audio Control Module																																																												
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
R	2016	Acadia	Body	Personal Audio Link Control Module																																																											
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																												
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																										V																	
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																										V																	
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																											
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																											
R	2016	Acadia	Body	Liftgate Control Module																																																											
R	2016	Acadia	Body	Seat Memory Control Module																																																											
R	2016	Acadia	Body	Front Seat Heating Control Module																																																											
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																											
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																											
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																											
R	2016	Acadia	Body	Parking Assist Control Module																																																											
R	2016	Acadia	Body	Frontview Camera Module																																																											
R	2016	Acadia	Body	Theft Deterrent Module																																																											
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																											
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Sonoma	Body	Body Control Module																																																											
S	2004	Sonoma	Body	Instrument Panel Cluster																																																											
S	2004	Sonoma	Body	Base Radio																																																											
S	2004	Sonoma	Body	Uplevel Radio																																																											
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																											
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2004	Canyon	Chassis	ABS Without Traction Control																																																											
S	2004	Canyon	Chassis	ABS With Traction Control																																																											
S	2004	Canyon	Body	Body Control Module																																																											
S	2004	Canyon	Body	Instrument Panel Cluster																																																											
S	2004	Canyon	Body	OnStar																																																											
S	2004	Canyon	Body	Base Radio																																																											
S	2004	Canyon	Body	Uplevel Radio																																																											
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2004	Envoy	Chassis	ABS Without Traction Control																																																											
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Envoy	Body	Amplifier (Bose)																																																											
S	2004	Envoy	Body	Body Control Module																																																											
S	2004	Envoy	Body	Driver Door Module																																																											
S	2004	Envoy	Body	Driver Seat Module																																																											
S	2004	Envoy	Body	Heating and Air Conditioning Auto																																																											
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																											
S	2004	Envoy	Body	Instrument Panel Cluster																																																											
S	2004	Envoy	Body	Lift Gate Module																																																											
S	2004	Envoy	Body	OnStar																																																											
S	2004	Envoy	Body	Passenger Door Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2004	Envoy	Body	Uplevel Radio																																																										
S	2004	Envoy	Body	Navigation Radio																																																										
S	2004	Envoy	Body	Rear Seat Audio																																																										
S	2004	Envoy	Body	Rear Seat Entertainment																																																										
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy XL	Body	Amplifier (Bose)																																																										
S	2004	Envoy XL	Body	Body Control Module																																																										
S	2004	Envoy XL	Body	Driver Door Module																																																										
S	2004	Envoy XL	Body	Driver Seat Module																																																										
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																										
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																										
S	2004	Envoy XL	Body	Lift Gate Module																																																										
S	2004	Envoy XL	Body	OnStar																																																										
S	2004	Envoy XL	Body	Passenger Door Module																																																										
S	2004	Envoy XL	Body	Uplevel Radio																																																										
S	2004	Envoy XL	Body	Navigation Radio																																																										
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																										
S	2004	Envoy XL	Body	Rear HVAC Manual																																																										
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																										
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																										
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																										
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																										
S	2004	Envoy XUV	Body	Body Control Module																																																										
S	2004	Envoy XUV	Body	Driver Door Module																																																										
S	2004	Envoy XUV	Body	Driver Seat Module																																																										
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																										
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																										
S	2004	Envoy XUV	Body	Lift Gate Module																																																										
S	2004	Envoy XUV	Body	OnStar																																																										
S	2004	Envoy XUV	Body	Passenger Door Module																																																										
S	2004	Envoy XUV	Body	Uplevel Radio																																																										
S	2004	Envoy XUV	Body	Navigation Radio																																																										
S	2004	Envoy XUV	Body	Rear Seat Audio																																																										
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																										
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Jimmy	Body	Body Control Module																																																										
S	2004	Jimmy	Body	Heating and Air Conditioning																																																										
S	2004	Jimmy	Body	Instrument Panel Cluster																																																										
S	2004	Jimmy	Body	Memory Seat Module																																																										
S	2004	Jimmy	Body	Base Radio																																																										
S	2004	Jimmy	Body	Uplevel Radio																																																										
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2005	Canyon	Chassis	ABS Without Traction Control																																																										
S	2005	Canyon	Chassis	ABS With Traction Control																																																										
S	2005	Canyon	Body	Body Control Module																																																										
S	2005	Canyon	Body	Instrument Panel Cluster																																																										
S	2005	Canyon	Body	Base Radio																																																										
S	2005	Canyon	Body	Uplevel Radio																																																										
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																											V															
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2005	Envoy	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy	Body	Body Control Module																																																										
S	2005	Envoy	Body	Disc Player and Video Display																																																										
S	2005	Envoy	Body	Driver Door Module																																																										
S	2005	Envoy	Body	Driver Seat Module																																																										
S	2005	Envoy	Body	Heating and Air Conditioning Auto																																																										
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2005	Envoy	Body	Instrument Panel Cluster																																																										
S	2005	Envoy	Body	Lift Gate Module																																																										
S	2005	Envoy	Body	Passenger Door Module																																																										
S	2005	Envoy	Body	Passenger Presence System																																																										
S	2005	Envoy	Body	Uplevel Radio																																																										
S	2005	Envoy	Body	Navigation Radio																																																										
S	2005	Envoy	Body	Rear Seat Audio																																																										
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																											V															

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																												
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																												
S	2005	Envoy XL	Body	Body Control Module																																																												
S	2005	Envoy XL	Body	Disc Player and Video Display																																																												
S	2005	Envoy XL	Body	Driver Door Module																																																												
S	2005	Envoy XL	Body	Driver Seat Module																																																												
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
S	2005	Envoy XL	Body	Instrument Panel Cluster																																																												
S	2005	Envoy XL	Body	Lift Gate Module																																																												
S	2005	Envoy XL	Body	Passenger Door Module																																																												
S	2005	Envoy XL	Body	Passenger Presence System																																																												
S	2005	Envoy XL	Body	Uplevel Radio																																																												
S	2005	Envoy XL	Body	Navigation Radio																																																												
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
S	2005	Envoy XL	Body	Rear HVAC Manual																																																												
S	2005	Envoy XL	Body	Rear Seat Audio																																																												
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																												
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																												
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								V																			
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																												
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																												
S	2005	Envoy XUV	Body	Body Control Module																																																												
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																												
S	2005	Envoy XUV	Body	Driver Door Module																																																												
S	2005	Envoy XUV	Body	Driver Seat Module																																																												
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																												
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																												
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																																												
S	2005	Envoy XUV	Body	Lift Gate Module																																																												
S	2005	Envoy XUV	Body	Passenger Door Module																																																												
S	2005	Envoy XUV	Body	Passenger Presence System																																																												
S	2005	Envoy XUV	Body	Uplevel Radio																																																												
S	2005	Envoy XUV	Body	Navigation Radio																																																												
S	2005	Envoy XUV	Body	Rear Seat Audio																																																												
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																												
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																												
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																												
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																												
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																												
S	2005	Jimmy	Body	Body Control Module																																																												
S	2005	Jimmy	Body	Heating and Air Conditioning																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2005	Jimmy	Body	Instrument Panel Cluster																																																											
S	2005	Jimmy	Body	Memory Seat Module																																																												
S	2005	Jimmy	Body	Base Radio																																																											
S	2005	Jimmy	Body	Uplevel Radio																																																											
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																											
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																											
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																											
S	2005	Sonoma	Body	Body Control Module																																																											
S	2005	Sonoma	Body	Instrument Panel Cluster																																																											
S	2005	Sonoma	Body	Base Radio																																																											
S	2005	Sonoma	Body	Uplevel Radio																																																											
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																											
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2006	Canyon	Chassis	ABS Without Traction Control																																																											
S	2006	Canyon	Chassis	ABS With Traction Control																																																											
S	2006	Canyon	Body	Body Control Module																																																											
S	2006	Canyon	Body	Instrument Panel Cluster																																																											
S	2006	Canyon	Body	Passenger Presence System																																																											
S	2006	Canyon	Body	Base Radio																																																											
S	2006	Canyon	Body	Uplevel Radio																																																											
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																																											
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								V																		
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								V																		
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2006	Envoy	Chassis	ABS/TCS/VSES																																																											
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																											
S	2006	Envoy	Body	Body Control Module																																																											
S	2006	Envoy	Body	Disc Player and Video Display																																																											
S	2006	Envoy	Body	Driver Door Module																																																											
S	2006	Envoy	Body	Driver Seat Module																																																											
S	2006	Envoy	Body	Heating and Air Conditioning Auto																																																											
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																																											
S	2006	Envoy	Body	Instrument Panel Cluster																																																											
S	2006	Envoy	Body	Lift Gate Module																																																											
S	2006	Envoy	Body	Passenger Door Module																																																											
S	2006	Envoy	Body	Passenger Presence System																																																											
S	2006	Envoy	Body	Uplevel Radio																																																											
S	2006	Envoy	Body	Navigation Radio																																																											
S	2006	Envoy	Body	Rear Seat Audio																																																											
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																																											
S	2006	Envoy	Body	Vehicle Theft Deterrent																																																											
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																									V																		
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																											
S	2006	Envoy XL	Body	Body Control Module																																																											
S	2006	Envoy XL	Body	Disc Player and Video Display																																																											
S	2006	Envoy XL	Body	Driver Door Module																																																											
S	2006	Envoy XL	Body	Driver Seat Module																																																											
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																											
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																											
S	2006	Envoy XL	Body	Instrument Panel Cluster																																																											
S	2006	Envoy XL	Body	Lift Gate Module																																																											
S	2006	Envoy XL	Body	Passenger Door Module																																																											
S	2006	Envoy XL	Body	Passenger Presence System																																																											
S	2006	Envoy XL	Body	Uplevel Radio																																																											
S	2006	Envoy XL	Body	Navigation Radio																																																											
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																											
S	2006	Envoy XL	Body	Rear HVAC Manual																																																											
S	2006	Envoy XL	Body	Rear Seat Audio																																																											
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																											
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																											
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																											
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																											
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																											
S	2007	Canyon	Body	Body Control Module																																																											
S	2007	Canyon	Body	Digital Radio Receiver																																																											
S	2007	Canyon	Body	Generator Battery Control Module																																																											
S	2007	Canyon	Body	Instrument Panel Cluster																																																											
S	2007	Canyon	Body	Passenger Presence System																																																											
S	2007	Canyon	Body	Base Radio																																																											
S	2007	Canyon	Body	Uplevel Radio																																																											
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																											
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2007	Envoy	Chassis	Electronic Brake Control Module																																																											
S	2007	Envoy	Body	Body Control Module																																																											
S	2007	Envoy	Body	Digital Radio Receiver																																																											
S	2007	Envoy	Body	Disc Player and Video Display																																																											
S	2007	Envoy	Body	Driver Door Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2007	Envoy	Body	Driver Seat Module																																																											
S	2007	Envoy	Body	Generator Battery Control Module																																																												
S	2007	Envoy	Body	HVAC Control Module Auto																																																												
S	2007	Envoy	Body	HVAC Control Module Manual																																																												
S	2007	Envoy	Body	Instrument Panel Cluster																																																												
S	2007	Envoy	Body	Lift Gate Module																																																												
S	2007	Envoy	Body	Passenger Door Module																																																												
S	2007	Envoy	Body	Passenger Presence System																																																												
S	2007	Envoy	Body	Uplevel Radio																																																												
S	2007	Envoy	Body	Navigation Radio																																																												
S	2007	Envoy	Body	Rear Seat Audio																																																												
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2007	Envoy	Body	Theft Deterrent Module																																																												
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																																												
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2008	Canyon	Body	Body Control Module																																																												
S	2008	Canyon	Body	Digital Radio Receiver																																																												
S	2008	Canyon	Body	Generator Battery Control Module																																																												
S	2008	Canyon	Body	Instrument Panel Cluster																																																												
S	2008	Canyon	Body	Passenger Presence System																																																												
S	2008	Canyon	Body	Base Radio																																																											
S	2008	Canyon	Body	Uplevel Radio																																																											
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2008	Canyon	Body	Theft Deterrent Module																																																											
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																																											
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2008	Envoy	Chassis	Electronic Brake Control Module																																																											
S	2008	Envoy	Body	Body Control Module																																																											
S	2008	Envoy	Body	Digital Radio Receiver																																																											
S	2008	Envoy	Body	Disc Player and Video Display																																																											
S	2008	Envoy	Body	Driver Door Module																																																											
S	2008	Envoy	Body	Driver Seat Module																																																											
S	2008	Envoy	Body	Generator Battery Control Module																																																											
S	2008	Envoy	Body	HVAC Control Module Auto																																																											
S	2008	Envoy	Body	HVAC Control Module Manual																																																											
S	2008	Envoy	Body	Instrument Panel Cluster																																																											
S	2008	Envoy	Body	Lift Gate Module																																																											
S	2008	Envoy	Body	Passenger Door Module																																																											
S	2008	Envoy	Body	Passenger Presence System																																																											
S	2008	Envoy	Body	Uplevel Radio																																																											
S	2008	Envoy	Body	Navigation Radio																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2008	Envoy	Body	Rear Seat Audio																																																											
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																																											
S	2008	Envoy	Body	Theft Deterrent Module																																																											
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																																											
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																											
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																											
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																											
S	2009	Canyon	Chassis	Electronic Brake Control Module																																																											
S	2009	Canyon	Body	Body Control Module																																																											
S	2009	Canyon	Body	Digital Radio Receiver																																																											
S	2009	Canyon	Body	Generator Battery Control Module																																																											
S	2009	Canyon	Body	Instrument Panel Cluster																																																											
S	2009	Canyon	Body	Passenger Presence System																																																											
S	2009	Canyon	Body	Base Radio																																																											
S	2009	Canyon	Body	Uplevel Radio																																																											
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2009	Canyon	Body	Theft Deterrent Module																																																											
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																											
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																											
S	2009	Envoy	Chassis	Electronic Brake Control Module																																																											
S	2009	Envoy	Body	Body Control Module																																																											
S	2009	Envoy	Body	Digital Radio Receiver																																																											
S	2009	Envoy	Body	Disc Player and Video Display																																																											
S	2009	Envoy	Body	Driver Door Module																																																											
S	2009	Envoy	Body	Driver Seat Module																																																											
S	2009	Envoy	Body	Generator Battery Control Module																																																											
S	2009	Envoy	Body	HVAC Control Module Auto																																																											
S	2009	Envoy	Body	HVAC Control Module Manual																																																											
S	2009	Envoy	Body	Instrument Panel Cluster																																																											
S	2009	Envoy	Body	Lift Gate Module																																																											
S	2009	Envoy	Body	Passenger Door Module																																																											
S	2009	Envoy	Body	Passenger Presence System																																																											
S	2009	Envoy	Body	Uplevel Radio																																																											
S	2009	Envoy	Body	Navigation Radio																																																											
S	2009	Envoy	Body	Rear Seat Audio																																																											
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																																											
S	2009	Envoy	Body	Theft Deterrent Module																																																											
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
S	2010	ALL	Chassis	Electronic Brake Control Module																																																										
S	2010	ALL	Body	Body Control Module																																																									
S	2010	ALL	Body	Digital Radio Receiver																																																									
S	2010	ALL	Body	Generator Battery Control Module																																																									
S	2010	ALL	Body	Instument Panel Cluster																																																									
S	2010	ALL	Body	Passenger Presence System																																																									
S	2010	ALL	Body	Personal Audio Link Module																																																									
S	2010	ALL	Body	Base Radio																																																									
S	2010	ALL	Body	Uplevel Radio																																																									
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
S	2010	ALL	Body	Theft Deterrent Module																																																									
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																									
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Sonoma	Body	Body Control Module																																																									
T	2004	Sonoma	Body	Instrument Panel Cluster																																																									
T	2004	Sonoma	Body	Base Radio																																																									
T	2004	Sonoma	Body	Uplevel Radio																																																									
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																									
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																									
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																									
T	2004	Canyon	Chassis	ABS Without Traction Control																																																									
T	2004	Canyon	Chassis	ABS With Traction Control																																																									
T	2004	Canyon	Body	Body Control Module																																																									
T	2004	Canyon	Body	Instrument Panel Cluster																																																									
T	2004	Canyon	Body	OnStar																																																									
T	2004	Canyon	Body	Base Radio																																																									
T	2004	Canyon	Body	Uplevel Radio																																																									
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																																									
T	2004	Canyon	Body	Instrument Panel Cluster																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																									
T	2004	Envoy	Chassis	ABS Without Traction Control																																																									
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Envoy	Body	Amplifier (Bose)																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2004	Envoy	Body	Body Control Module																																																									
T	2004	Envoy	Body	Driver Door Module																																																									
T	2004	Envoy	Body	Driver Seat Module																																																									
T	2004	Envoy	Body	Heating and Air Conditioning Auto																																																									
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																																									
T	2004	Envoy	Body	Instrument Panel Cluster																																																									
T	2004	Envoy	Body	Lift Gate Module																																																									
T	2004	Envoy	Body	OnStar																																																									
T	2004	Envoy	Body	Passenger Door Module																																																									
T	2004	Envoy	Body	Uplevel Radio																																																									
T	2004	Envoy	Body	Navigation Radio																																																									
T	2004	Envoy	Body	Rear Seat Audio																																																									
T	2004	Envoy	Body	Rear Seat Entertainment																																																									
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																																									
T	2004	Envoy	Body	Vehicle Theft Deterrent																																																									
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																									
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																									
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																									
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																									
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																									
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Envoy XL	Body	Amplifier (Bose)																																																									
T	2004	Envoy XL	Body	Body Control Module																																																									
T	2004	Envoy XL	Body	Driver Door Module																																																									
T	2004	Envoy XL	Body	Driver Seat Module																																																									
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																									
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																									
T	2004	Envoy XL	Body	Instrument Panel Cluster																																																									
T	2004	Envoy XL	Body	Lift Gate Module																																																									
T	2004	Envoy XL	Body	OnStar																																																									
T	2004	Envoy XL	Body	Passenger Door Module																																																									
T	2004	Envoy XL	Body	Uplevel Radio																																																									
T	2004	Envoy XL	Body	Navigation Radio																																																									
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																									
T	2004	Envoy XL	Body	Rear HVAC Manual																																																									
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																									
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																									
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																									
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																									
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																									
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																									
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																									
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																									
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2004	Envoy XUV	Body	Body Control Module																																																											
T	2004	Envoy XUV	Body	Driver Door Module																																																												
T	2004	Envoy XUV	Body	Driver Seat Module																																																												
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																												
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																												
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																																												
T	2004	Envoy XUV	Body	Lift Gate Module																																																												
T	2004	Envoy XUV	Body	OnStar																																																												
T	2004	Envoy XUV	Body	Passenger Door Module																																																												
T	2004	Envoy XUV	Body	Uplevel Radio																																																												
T	2004	Envoy XUV	Body	Navigation Radio																																																												
T	2004	Envoy XUV	Body	Rear Seat Audio																																																												
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																												
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																												
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																												
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																												
T	2004	Jimmy	Body	Body Control Module																																																												
T	2004	Jimmy	Body	Heating and Air Conditioning																																																												
T	2004	Jimmy	Body	Instrument Panel Cluster																																																												
T	2004	Jimmy	Body	Memory Seat Module																																																												
T	2004	Jimmy	Body	Base Radio																																																												
T	2004	Jimmy	Body	Uplevel Radio																																																												
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																												
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2005	Canyon	Chassis	ABS Without Traction Control																																																												
T	2005	Canyon	Chassis	ABS With Traction Control																																																												
T	2005	Canyon	Body	Body Control Module																																																												
T	2005	Canyon	Body	Instrument Panel Cluster																																																												
T	2005	Canyon	Body	Base Radio																																																												
T	2005	Canyon	Body	Uplevel Radio																																																												
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																											
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																											
T	2005	Envoy	Chassis	ABS Without Traction Control																																																												
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Envoy	Body	Body Control Module																																																												
T	2005	Envoy	Body	Disc Player and Video Display																																																												
T	2005	Envoy	Body	Driver Door Module																																																												
T	2005	Envoy	Body	Driver Seat Module																																																												
T	2005	Envoy	Body	Heating and Air Conditioning Auto																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																																									
T	2005	Envoy	Body	Instrument Panel Cluster																																																									
T	2005	Envoy	Body	Lift Gate Module																																																									
T	2005	Envoy	Body	Passenger Door Module																																																									
T	2005	Envoy	Body	Passenger Presence System																																																									
T	2005	Envoy	Body	Uplevel Radio																																																									
T	2005	Envoy	Body	Navigation Radio																																																									
T	2005	Envoy	Body	Rear Seat Audio																																																									
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																																									
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																																									
T	2005	Envoy	Body	Vehicle Theft Deterrent																																																									
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																									
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																									V																
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																									
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																									
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																									
T	2005	Envoy XL	Body	Body Control Module																																																									
T	2005	Envoy XL	Body	Disc Player and Video Display																																																									
T	2005	Envoy XL	Body	Driver Door Module																																																									
T	2005	Envoy XL	Body	Driver Seat Module																																																									
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																									
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																									
T	2005	Envoy XL	Body	Instrument Panel Cluster																																																									
T	2005	Envoy XL	Body	Lift Gate Module																																																									
T	2005	Envoy XL	Body	Passenger Door Module																																																									
T	2005	Envoy XL	Body	Passenger Presence System																																																									
T	2005	Envoy XL	Body	Uplevel Radio																																																									
T	2005	Envoy XL	Body	Navigation Radio																																																									
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																									
T	2005	Envoy XL	Body	Rear HVAC Manual																																																									
T	2005	Envoy XL	Body	Rear Seat Audio																																																									
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																									
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																									
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																									
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																									
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																									V																
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																									
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																									
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																									
T	2005	Envoy XUV	Body	Body Control Module																																																									
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																									
T	2005	Envoy XUV	Body	Driver Door Module																																																									
T	2005	Envoy XUV	Body	Driver Seat Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																										
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																										
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																																										
T	2005	Envoy XUV	Body	Lift Gate Module																																																										
T	2005	Envoy XUV	Body	Passenger Door Module																																																										
T	2005	Envoy XUV	Body	Passenger Presence System																																																										
T	2005	Envoy XUV	Body	Uplevel Radio																																																										
T	2005	Envoy XUV	Body	Navigation Radio																																																										
T	2005	Envoy XUV	Body	Rear Seat Audio																																																										
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																										
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																										
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Jimmy	Body	Body Control Module																																																										
T	2005	Jimmy	Body	Heating and Air Conditioning																																																										
T	2005	Jimmy	Body	Instrument Panel Cluster																																																										
T	2005	Jimmy	Body	Memory Seat Module																																																										
T	2005	Jimmy	Body	Base Radio																																																										
T	2005	Jimmy	Body	Uplevel Radio																																																										
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																										
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																										
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Sonoma	Body	Body Control Module																																																										
T	2005	Sonoma	Body	Instrument Panel Cluster																																																										
T	2005	Sonoma	Body	Base Radio																																																										
T	2005	Sonoma	Body	Uplevel Radio																																																										
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																										
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
T	2006	Canyon	Chassis	ABS Without Traction Control																																																										
T	2006	Canyon	Chassis	ABS With Traction Control																																																										
T	2006	Canyon	Body	Body Control Module																																																										
T	2006	Canyon	Body	Instrument Panel Cluster																																																										
T	2006	Canyon	Body	Passenger Presence System																																																										
T	2006	Canyon	Body	Base Radio																																																										
T	2006	Canyon	Body	Uplevel Radio																																																										
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																																										
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																									V																	

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																									V																			
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2006	Envoy	Chassis	ABS/TCS/VSES																																																												
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																												
T	2006	Envoy	Body	Body Control Module																																																												
T	2006	Envoy	Body	Disc Player and Video Display																																																												
T	2006	Envoy	Body	Driver Door Module																																																												
T	2006	Envoy	Body	Driver Seat Module																																																												
T	2006	Envoy	Body	Heating and Air Conditioning Auto																																																												
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																																												
T	2006	Envoy	Body	Instrument Panel Cluster																																																												
T	2006	Envoy	Body	Lift Gate Module																																																												
T	2006	Envoy	Body	Passenger Door Module																																																												
T	2006	Envoy	Body	Passenger Presence System																																																												
T	2006	Envoy	Body	Uplevel Radio																																																												
T	2006	Envoy	Body	Navigation Radio																																																												
T	2006	Envoy	Body	Rear Seat Audio																																																												
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2006	Envoy	Body	Vehicle Theft Deterrent																																																												
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																																												
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																									V																			
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																												
T	2006	Envoy XL	Body	Body Control Module																																																												
T	2006	Envoy XL	Body	Disc Player and Video Display																																																												
T	2006	Envoy XL	Body	Driver Door Module																																																												
T	2006	Envoy XL	Body	Driver Seat Module																																																												
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
T	2006	Envoy XL	Body	Instrument Panel Cluster																																																												
T	2006	Envoy XL	Body	Lift Gate Module																																																												
T	2006	Envoy XL	Body	Passenger Door Module																																																												
T	2006	Envoy XL	Body	Passenger Presence System																																																												
T	2006	Envoy XL	Body	Uplevel Radio																																																												
T	2006	Envoy XL	Body	Navigation Radio																																																												
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
T	2006	Envoy XL	Body	Rear HVAC Manual																																																												
T	2006	Envoy XL	Body	Rear Seat Audio																																																												
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																												
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																												
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																												
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																												
T	2007	Canyon	Body	Body Control Module																																																												
T	2007	Canyon	Body	Digital Radio Receiver																																																												
T	2007	Canyon	Body	Generator Battery Control Module																																																												
T	2007	Canyon	Body	Instrument Panel Cluster																																																												
T	2007	Canyon	Body	Passenger Presence System																																																												
T	2007	Canyon	Body	Base Radio																																																												
T	2007	Canyon	Body	Uplevel Radio																																																												
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																												
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																												
T	2007	Envoy	Chassis	Electronic Brake Control Module																																																												
T	2007	Envoy	Body	Body Control Module																																																												
T	2007	Envoy	Body	Digital Radio Receiver																																																												
T	2007	Envoy	Body	Disc Player and Video Display																																																												
T	2007	Envoy	Body	Driver Door Module																																																												
T	2007	Envoy	Body	Driver Seat Module																																																												
T	2007	Envoy	Body	Generator Battery Control Module																																																												
T	2007	Envoy	Body	HVAC Control Module Auto																																																												
T	2007	Envoy	Body	HVAC Control Module Manual																																																												
T	2007	Envoy	Body	Instrument Panel Cluster																																																												
T	2007	Envoy	Body	Lift Gate Module																																																												
T	2007	Envoy	Body	Passenger Door Module																																																												
T	2007	Envoy	Body	Passenger Presence System																																																												
T	2007	Envoy	Body	Uplevel Radio																																																												
T	2007	Envoy	Body	Navigation Radio																																																												
T	2007	Envoy	Body	Rear Seat Audio																																																												
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2007	Envoy	Body	Theft Deterrent Module																																																												
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																																												
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2008	Canyon	Body	Body Control Module																																																										
T	2008	Canyon	Body	Digital Radio Receiver																																																										
T	2008	Canyon	Body	Generator Battery Control Module																																																										
T	2008	Canyon	Body	Instrument Panel Cluster																																																										
T	2008	Canyon	Body	Passenger Presence System																																																										
T	2008	Canyon	Body	Base Radio																																																										
T	2008	Canyon	Body	Uplevel Radio																																																										
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2008	Canyon	Body	Theft Deterrent Module																																																										
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2008	Envoy	Chassis	Electronic Brake Control Module																																																										
T	2008	Envoy	Body	Body Control Module																																																										
T	2008	Envoy	Body	Digital Radio Receiver																																																										
T	2008	Envoy	Body	Disc Player and Video Display																																																										
T	2008	Envoy	Body	Driver Door Module																																																										
T	2008	Envoy	Body	Driver Seat Module																																																										
T	2008	Envoy	Body	Generator Battery Control Module																																																										
T	2008	Envoy	Body	HVAC Control Module Auto																																																										
T	2008	Envoy	Body	HVAC Control Module Manual																																																										
T	2008	Envoy	Body	Instrument Panel Cluster																																																										
T	2008	Envoy	Body	Lift Gate Module																																																										
T	2008	Envoy	Body	Passenger Door Module																																																										
T	2008	Envoy	Body	Passenger Presence System																																																										
T	2008	Envoy	Body	Uplevel Radio																																																										
T	2008	Envoy	Body	Navigation Radio																																																										
T	2008	Envoy	Body	Rear Seat Audio																																																										
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2008	Envoy	Body	Theft Deterrent Module																																																										
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																										
T	2009	Canyon	Chassis	Electronic Brake Control Module																																																										
T	2009	Canyon	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2009	Canyon	Body	Digital Radio Receiver																																																										
T	2009	Canyon	Body	Generator Battery Control Module																																																										
T	2009	Canyon	Body	Instrument Panel Cluster																																																										
T	2009	Canyon	Body	Passenger Presence System																																																										
T	2009	Canyon	Body	Base Radio																																																										
T	2009	Canyon	Body	Uplevel Radio																																																										
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2009	Canyon	Body	Theft Deterrent Module																																																										
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																										
T	2009	Envoy	Body	Body Control Module																																																										
T	2009	Envoy	Body	Digital Radio Receiver																																																										
T	2009	Envoy	Body	Disc Player and Video Display																																																										
T	2009	Envoy	Body	Driver Door Module																																																										
T	2009	Envoy	Body	Driver Seat Module																																																										
T	2009	Envoy	Body	Generator Battery Control Module																																																										
T	2009	Envoy	Body	HVAC Control Module Auto																																																										
T	2009	Envoy	Body	HVAC Control Module Manual																																																										
T	2009	Envoy	Body	Instrument Panel Cluster																																																										
T	2009	Envoy	Body	Lift Gate Module																																																										
T	2009	Envoy	Body	Passenger Door Module																																																										
T	2009	Envoy	Body	Passenger Presence System																																																										
T	2009	Envoy	Body	Uplevel Radio																																																										
T	2009	Envoy	Body	Navigation Radio																																																										
T	2009	Envoy	Body	Rear Seat Audio																																																										
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2009	Envoy	Body	Theft Deterrent Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
T	2010	ALL	Chassis	Electronic Brake Control Module																																																										
T	2010	ALL	Body	Body Control Module																																																										
T	2010	ALL	Body	Digital Radio Receiver																																																										
T	2010	ALL	Body	Generator Battery Control Module																																																										
T	2010	ALL	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
T	2010	ALL	Body	Passenger Presence System																																																											
T	2010	ALL	Body	Personal Audio Link Module																																																												
T	2010	ALL	Body	Base Radio																																																												
T	2010	ALL	Body	Uplevel Radio																																																												
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2010	ALL	Body	Theft Deterrent Module																																																												
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																												
V	2007	ALL	Powertrain	Engine Control Module																																																												
V	2007	ALL	Powertrain	Rear Drive System																																																												
V	2007	ALL	Powertrain	Transmission Control Module																																																												
V	2007	ALL	Chassis	Electronic Brake Control Module																																																												
V	2007	ALL	Body	Body Control Module																																																												
V	2007	ALL	Body	Digital Radio Receiver																																																												
V	2007	ALL	Body	Driver Door Switch																																																												
V	2007	ALL	Body	Head Up Display																																																												
V	2007	ALL	Body	Heated Seat Module																																																												
V	2007	ALL	Body	HVAC Control Module Auto																																																												
V	2007	ALL	Body	HVAC Control Module Manual																																																												
V	2007	ALL	Body	Instrument Panel Cluster																																																												
V	2007	ALL	Body	Lift Gate Module																																																												
V	2007	ALL	Body	Park Assist Module																																																												
V	2007	ALL	Body	Passenger Door Switch																																																												
V	2007	ALL	Body	Passenger Presence System																																																												
V	2007	ALL	Body	Radio																																																												
V	2007	ALL	Body	Rear HVAC/RSA																																																												
V	2007	ALL	Body	Rollover Sensor																																																												
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2007	ALL	Body	Theft Deterrent Module																																																												
V	2008	ALL	Powertrain	Engine Control Module																																																												
V	2008	ALL	Powertrain	Rear Drive System																																																												
V	2008	ALL	Powertrain	Transmission Control Module																																																												
V	2008	ALL	Chassis	Electronic Brake Control Module																																																												
V	2008	ALL	Body	Body Control Module																																																												
V	2008	ALL	Body	Digital Radio Receiver																																																												
V	2008	ALL	Body	Driver Door Switch																																																												
V	2008	ALL	Body	Head Up Display																																																												
V	2008	ALL	Body	Heated Seat Module																																																												
V	2008	ALL	Body	HVAC Control Module Auto																																																												
V	2008	ALL	Body	HVAC Control Module Manual																																																												
V	2008	ALL	Body	Instrument Panel Cluster																																																												
V	2008	ALL	Body	Lift Gate Module																																																												
V	2008	ALL	Body	Park Assist Module																																																												
V	2008	ALL	Body	Passenger Door Switch																																																												
V	2008	ALL	Body	Passenger Presence System																																																												
V	2008	ALL	Body	Radio																																																												
V	2008	ALL	Body	Rear HVAC/RSA																																																												
V	2008	ALL	Body	Rollover Sensor																																																												
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2008	ALL	Body	Theft Deterrent Module																																																												
V	2009	ALL	Powertrain	Engine Control Module																																																												
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
V	2009	ALL	Powertrain	Rear Drive System																																																										
V	2009	ALL	Powertrain	Transmission Control Module																																																										
V	2009	ALL	Chassis	Electronic Brake Control Module																																																										
V	2009	ALL	Body	Body Control Module																																																										
V	2009	ALL	Body	Digital Radio Receiver																																																										
V	2009	ALL	Body	Driver Door Switch																																																										
V	2009	ALL	Body	Head Up Display																																																										
V	2009	ALL	Body	Heated Seat Module																																																										
V	2009	ALL	Body	HVAC Control Module Auto																																																										
V	2009	ALL	Body	HVAC Control Module Manual																																																										
V	2009	ALL	Body	Instrument Panel Cluster																																																										
V	2009	ALL	Body	Lift Gate Module																																																										
V	2009	ALL	Body	Park Assist Module																																																										
V	2009	ALL	Body	Passenger Door Switch																																																										
V	2009	ALL	Body	Passenger Presence System																																																										
V	2009	ALL	Body	Radio																																																										
V	2009	ALL	Body	Rear HVAC/RSA																																																										
V	2009	ALL	Body	Rollover Sensor																																																										
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2009	ALL	Body	Theft Deterrent Module																																																										
V	2010	ALL	Powertrain	Engine Control Module																																																										
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2010	ALL	Powertrain	Rear Drive System																																																										
V	2010	ALL	Powertrain	Transmission Control Module																																																										
V	2010	ALL	Chassis	Electronic Brake Control Module																																																										
V	2010	ALL	Body	Body Control Module																																																										
V	2010	ALL	Body	Digital Radio Receiver																																																										
V	2010	ALL	Body	Driver Door Switch																																																										
V	2010	ALL	Body	Head Up Display																																																										
V	2010	ALL	Body	Heated Seat Module																																																										
V	2010	ALL	Body	HVAC Control Module Auto																																																										
V	2010	ALL	Body	HVAC Control Module Manual																																																										
V	2010	ALL	Body	Instrument Panel Cluster																																																										
V	2010	ALL	Body	Lift Gate Module																																																										
V	2010	ALL	Body	Park Assist Module																																																										
V	2010	ALL	Body	Passenger Door Switch																																																										
V	2010	ALL	Body	Passenger Presence System																																																										
V	2010	ALL	Body	Radio																																																										
V	2010	ALL	Body	Rear HVAC/RSA																																																										
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2010	ALL	Body	Theft Deterrent Module																																																										
V	2011	ALL	Powertrain	Engine Control Module																																																										
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2011	ALL	Powertrain	Rear Drive System																																																										
V	2011	ALL	Powertrain	Transmission Control Module																																																										
V	2011	ALL	Chassis	Electronic Brake Control Module																																																										
V	2011	ALL	Body	Body Control Module																																																										
V	2011	ALL	Body	Digital Radio Receiver																																																										
V	2011	ALL	Body	Driver Door Switch																																																										
V	2011	ALL	Body	Head Up Display																																																										
V	2011	ALL	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
V	2011	ALL	Body	HVAC Control Module Auto																																																											
V	2011	ALL	Body	HVAC Control Module Manual																																																												
V	2011	ALL	Body	Instrument Panel Cluster																																																												
V	2011	ALL	Body	Lift Gate Module																																																												
V	2011	ALL	Body	Park Assist Module																																																												
V	2011	ALL	Body	Passenger Door Switch																																																												
V	2011	ALL	Body	Passenger Presence System																																																												
V	2011	ALL	Body	Radio																																																												
V	2011	ALL	Body	Rear HVAC/RSA																																																												
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2011	ALL	Body	Theft Deterrent Module																																																												
V	2012	ALL	Powertrain	Engine Control Module																																																												
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2012	ALL	Powertrain	Rear Drive System																																																												
V	2012	ALL	Powertrain	Transmission Control Module																																																												
V	2012	ALL	Chassis	Electronic Brake Control Module																																																												
V	2012	ALL	Body	Body Control Module																																																												
V	2012	ALL	Body	Digital Radio Receiver																																																												
V	2012	ALL	Body	Driver Door Switch																																																												
V	2012	ALL	Body	Head Up Display																																																												
V	2012	ALL	Body	Heated Seat Module																																																												
V	2012	ALL	Body	HVAC Control Module Auto																																																												
V	2012	ALL	Body	HVAC Control Module Manual																																																												
V	2012	ALL	Body	Instrument Panel Cluster																																																												
V	2012	ALL	Body	Lift Gate Module																																																												
V	2012	ALL	Body	Park Assist Module																																																												
V	2012	ALL	Body	Passenger Door Switch																																																												
V	2012	ALL	Body	Passenger Presence System																																																												
V	2012	ALL	Body	Radio																																																												
V	2012	ALL	Body	Rear HVAC/RSA																																																												
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2012	ALL	Body	Theft Deterrent Module																																																												
V	2013	ALL	Powertrain	Engine Control Module																																																												
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2013	ALL	Powertrain	Rear Drive System																																																												
V	2013	ALL	Powertrain	Transmission Control Module																																																												
V	2013	ALL	Chassis	Electronic Brake Control Module																																																												
V	2013	ALL	Body	Body Control Module																																																												
V	2013	ALL	Body	Digital Radio Receiver																																																												
V	2013	ALL	Body	Driver Door Switch																																																												
V	2013	ALL	Body	Head Up Display																																																												
V	2013	ALL	Body	Heated Seat Module																																																												
V	2013	ALL	Body	HVAC Control Module Auto																																																												
V	2013	ALL	Body	HVAC Control Module Manual																																																												
V	2013	ALL	Body	Instrument Panel Cluster																																																												
V	2013	ALL	Body	Left Side Object Detection Module																																																												
V	2013	ALL	Body	Lift Gate Module																																																												
V	2013	ALL	Body	Park Assist Module																																																												
V	2013	ALL	Body	Passenger Door Switch																																																												
V	2013	ALL	Body	Passenger Presence System																																																												
V	2013	ALL	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
V	2013	ALL	Body	Rear HVAC/RSA																																																									
V	2013	ALL	Body	Right Side Object Detection Module																																																									
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2013	ALL	Body	Theft Deterrent Module																																																									
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2014	Acadia	Powertrain	Chassis Control Module																																																									
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																									
V	2014	Acadia	Chassis	Electronic Brake Control Module																																																									
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																									
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2014	Acadia	Body	Passenger Presence Module																																																									
V	2014	Acadia	Body	Instrument Cluster																																																									
V	2014	Acadia	Body	Head-Up Display Module																																																									
V	2014	Acadia	Body	Radio																																																									
V	2014	Acadia	Body	Rear Audio Control Module																																																									
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																									
V	2014	Acadia	Body	Personal Audio Link Control Module																																																									
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																										V														
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																										V														
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																									
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																									
V	2014	Acadia	Body	Liftgate Control Module																																																									
V	2014	Acadia	Body	Seat Memory Control Module																																																									
V	2014	Acadia	Body	Front Seat Heating Control Module																																																									
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																									
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																									
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																									
V	2014	Acadia	Body	Parking Assist Control Module																																																									
V	2014	Acadia	Body	Frontview Camera Module																																																									
V	2014	Acadia	Body	Theft Deterrent Module																																																									
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																									
V	2015	Acadia	Chassis	Electronic Brake Control Module																																																									
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																									
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2015	Acadia	Body	Passenger Presence Module																																																									
V	2015	Acadia	Body	Instrument Cluster																																																									
V	2015	Acadia	Body	Head-Up Display Module																																																									
V	2015	Acadia	Body	Radio																																																									
V	2015	Acadia	Body	Rear Audio Control Module																																																									
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																									
V	2015	Acadia	Body	Personal Audio Link Control Module																																																									
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																										V														

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																									V														
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																							
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																							
V	2015	Acadia	Body	Liftgate Control Module																																																							
V	2015	Acadia	Body	Seat Memory Control Module																																																							
V	2015	Acadia	Body	Front Seat Heating Control Module																																																							
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																							
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																							
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																							
V	2015	Acadia	Body	Parking Assist Control Module																																																							
V	2015	Acadia	Body	Frontview Camera Module																																																							
V	2015	Acadia	Body	Theft Deterrent Module																																																							
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																							
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																							
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																							
V	2016	Acadia	Chassis	Electronic Brake Control Module																																																							
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																							
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																							
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																							
V	2016	Acadia	Body	Passenger Presence Module																																																							
V	2016	Acadia	Body	Instrument Cluster																																																							
V	2016	Acadia	Body	Head-Up Display Module																																																							
V	2016	Acadia	Body	Radio																																																							
V	2016	Acadia	Body	Rear Audio Control Module																																																							
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																							
V	2016	Acadia	Body	Personal Audio Link Control Module																																																							
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																							
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																									V														
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																									V														
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																							
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																							
V	2016	Acadia	Body	Liftgate Control Module																																																							
V	2016	Acadia	Body	Seat Memory Control Module																																																							
V	2016	Acadia	Body	Front Seat Heating Control Module																																																							
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																							
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																							
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																							
V	2016	Acadia	Body	Parking Assist Control Module																																																							
V	2016	Acadia	Body	Frontview Camera Module																																																							
V	2016	Acadia	Body	Theft Deterrent Module																																																							
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																							
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																							
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																							
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																							
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																							
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																							
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																							
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																							
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																							

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																						V																																				
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																				
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V	V	V																																																				
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
1	2011	Sierra	Chassis	Electronic Suspension Control																																																										
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																										
1	2011	Sierra	Body	Amplifier (Bose)																																																										
1	2011	Sierra	Body	Body Control Module																																																										
1	2011	Sierra	Body	Body Control Module (aux.)																																																										
1	2011	Sierra	Body	Digital Radio Receiver																																																										
1	2011	Sierra	Body	Driver Door Switch																																																										
1	2011	Sierra	Body	HVAC Control Module Auto																																																										
1	2011	Sierra	Body	HVAC Control Module Manual																																																										
1	2011	Sierra	Body	Instrument Panel Cluster																																																										
1	2011	Sierra	Body	Memory Seat Module																																																										
1	2011	Sierra	Body	Park Assist Module																																																										
1	2011	Sierra	Body	Passenger Door Switch																																																										
1	2011	Sierra	Body	Passenger Presence System																																																										
1	2011	Sierra	Body	Radio																																																										
1	2011	Sierra	Body	Rear Heated Seat Module																																																										
1	2011	Sierra	Body	Rear HVAC/RSA																																																										
1	2011	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2011	Sierra	Body	Theft Deterrent Module																																																										
1	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																										
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																										
1	2011	Sierra Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2011	Sierra Hybrid	Body	Driver Door Switch																																																										
1	2011	Sierra Hybrid	Body	Heated Seat Module																																																										
1	2011	Sierra Hybrid	Body	HVAC Control Module																																																										
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2011	Sierra Hybrid	Body	Park Assist Module																																																										
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																																										
1	2011	Sierra Hybrid	Body	Passenger Presence System																																																										
1	2011	Sierra Hybrid	Body	Radio																																																										
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2011	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2011	Yukon	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																										
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon	Body	Amplifier (Bose)																																																										
1	2011	Yukon	Body	Assist Step Controller																																																										
1	2011	Yukon	Body	Body Control Module																																																										
1	2011	Yukon	Body	Body Control Module (aux.)																																																										
1	2011	Yukon	Body	Digital Radio Receiver																																																										
1	2011	Yukon	Body	Driver Door Switch																																																										
1	2011	Yukon	Body	HVAC Control Module Auto																																																										
1	2011	Yukon	Body	HVAC Control Module Manual																																																										
1	2011	Yukon	Body	Instrument Panel Cluster																																																										
1	2011	Yukon	Body	Left Side Object Detection Module																																																										
1	2011	Yukon	Body	Lift Gate Module																																																										
1	2011	Yukon	Body	Memory Seat Module																																																										
1	2011	Yukon	Body	Park Assist Module																																																										
1	2011	Yukon	Body	Passenger Door Switch																																																										
1	2011	Yukon	Body	Passenger Presence System																																																										
1	2011	Yukon	Body	Radio																																																										
1	2011	Yukon	Body	Rear Heated Seat Module																																																										
1	2011	Yukon	Body	Rear HVAC/RSA																																																										
1	2011	Yukon	Body	Right Side Object Detection Module																																																										
1	2011	Yukon	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon	Body	Theft Deterrent Module																																																										
1	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																											
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																											
1	2011	Yukon Hybrid	Body	Body Control Module																																																											
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																											
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																											
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																											
1	2011	Yukon Hybrid	Body	HVAC Control Module																																																											
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
1	2011	Yukon Hybrid	Body	Lift Gate Module																																																											
1	2011	Yukon Hybrid	Body	Park Assist Module																																																											
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																											
1	2011	Yukon Hybrid	Body	Passenger Presence System																																																											
1	2011	Yukon Hybrid	Body	Radio																																																											
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																											
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																											
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																											
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																											
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
1	2011	Yukon XL	Body	Amplifier (Bose)																																																											
1	2011	Yukon XL	Body	Assist Step Controller																																																											
1	2011	Yukon XL	Body	Body Control Module																																																											
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																											
1	2011	Yukon XL	Body	Digital Radio Receiver																																																											
1	2011	Yukon XL	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2011	Yukon XL	Body	HVAC Control Module Auto																																																											
1	2011	Yukon XL	Body	HVAC Control Module Manual																																																											
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																											
1	2011	Yukon XL	Body	Left Side Object Detection Module																																																											
1	2011	Yukon XL	Body	Lift Gate Module																																																											
1	2011	Yukon XL	Body	Memory Seat Module																																																											
1	2011	Yukon XL	Body	Park Assist Module																																																											
1	2011	Yukon XL	Body	Passenger Door Switch																																																											
1	2011	Yukon XL	Body	Passenger Presence System																																																											
1	2011	Yukon XL	Body	Radio																																																											
1	2011	Yukon XL	Body	Rear Heated Seat Module																																																											
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																											
1	2011	Yukon XL	Body	Right Side Object Detection Module																																																											
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
1	2011	Yukon XL	Body	Theft Deterrent Module																																																											
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																							V																																				
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																						
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																											
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																											
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V	V	V																																																						
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																											
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																											
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																											
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
1	2012	Sierra	Chassis	Electronic Suspension Control																																																											
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																											
1	2012	Sierra	Body	Amplifier (Bose)																																																											
1	2012	Sierra	Body	Body Control Module																																																											
1	2012	Sierra	Body	Body Control Module (aux.)																																																											
1	2012	Sierra	Body	Digital Radio Receiver																																																											
1	2012	Sierra	Body	Driver Door Switch																																																											
1	2012	Sierra	Body	HVAC Control Module Auto																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2012	Sierra	Body	HVAC Control Module Manual																																																											
1	2012	Sierra	Body	Instrument Panel Cluster																																																											
1	2012	Sierra	Body	Memory Seat Module																																																											
1	2012	Sierra	Body	Park Assist Module																																																											
1	2012	Sierra	Body	Passenger Door Switch																																																											
1	2012	Sierra	Body	Passenger Presence System																																																											
1	2012	Sierra	Body	Radio																																																											
1	2012	Sierra	Body	Navigation Radio																																																											
1	2012	Sierra	Body	Rear Heated Seat Module																																																											
1	2012	Sierra	Body	Rear HVAC/RSA																																																											
1	2012	Sierra	Body	Supplemental Inflatable Restraint																																																											
1	2012	Sierra	Body	Theft Deterrent Module																																																											
1	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																											
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																											
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																											
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																											
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																											
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																											
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																											
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																											
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																											
1	2012	Sierra Hybrid	Body	Body Control Module																																																											
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																											
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																											
1	2012	Sierra Hybrid	Body	Driver Door Switch																																																											
1	2012	Sierra Hybrid	Body	Heated Seat Module																																																											
1	2012	Sierra Hybrid	Body	HVAC Control Module																																																											
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																											
1	2012	Sierra Hybrid	Body	Park Assist Module																																																											
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																																											
1	2012	Sierra Hybrid	Body	Passenger Presence System																																																											
1	2012	Sierra Hybrid	Body	Radio																																																											
1	2012	Sierra Hybrid	Body	Navigation Radio																																																											
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																											
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																											
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																											
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																											
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																											
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
1	2012	Yukon	Chassis	Electronic Brake Control Module																																																											
1	2012	Yukon	Chassis	Electronic Suspension Control																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																											
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon	Body	Amplifier (Bose)																																																											
1	2012	Yukon	Body	Assist Step Controller																																																											
1	2012	Yukon	Body	Body Control Module																																																											
1	2012	Yukon	Body	Body Control Module (aux.)																																																											
1	2012	Yukon	Body	Digital Radio Receiver																																																											
1	2012	Yukon	Body	Driver Door Switch																																																											
1	2012	Yukon	Body	HVAC Control Module Auto																																																											
1	2012	Yukon	Body	HVAC Control Module Manual																																																											
1	2012	Yukon	Body	Instrument Panel Cluster																																																											
1	2012	Yukon	Body	Left Side Object Detection Module																																																											
1	2012	Yukon	Body	Lift Gate Module																																																											
1	2012	Yukon	Body	Memory Seat Module																																																											
1	2012	Yukon	Body	Park Assist Module																																																											
1	2012	Yukon	Body	Passenger Door Switch																																																											
1	2012	Yukon	Body	Passenger Presence System																																																											
1	2012	Yukon	Body	Radio																																																											
1	2012	Yukon	Body	Navigation Radio																																																											
1	2012	Yukon	Body	Rear Heated Seat Module																																																											
1	2012	Yukon	Body	Rear HVAC/RSA																																																											
1	2012	Yukon	Body	Right Side Object Detection Module																																																											
1	2012	Yukon	Body	Supplemental Inflatable Restraint																																																											
1	2012	Yukon	Body	Theft Deterrent Module																																																											
1	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																											
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																											
1	2012	Yukon Hybrid	Body	Body Control Module																																																											
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																											
1	2012	Yukon Hybrid	Body	Driver Door Switch																																																											
1	2012	Yukon Hybrid	Body	Heated Seat Module																																																											
1	2012	Yukon Hybrid	Body	HVAC Control Module																																																											
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
1	2012	Yukon Hybrid	Body	Lift Gate Module																																																											
1	2012	Yukon Hybrid	Body	Park Assist Module																																																											
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																																											
1	2012	Yukon Hybrid	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2012	Yukon Hybrid	Body	Radio																																																											
1	2012	Yukon Hybrid	Body	Navigation Radio																																																											
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																											
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																											
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																											
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																											
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon XL	Body	Amplifier (Bose)																																																											
1	2012	Yukon XL	Body	Assist Step Controller																																																											
1	2012	Yukon XL	Body	Body Control Module																																																											
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																											
1	2012	Yukon XL	Body	Digital Radio Receiver																																																											
1	2012	Yukon XL	Body	Driver Door Switch																																																											
1	2012	Yukon XL	Body	HVAC Control Module Auto																																																											
1	2012	Yukon XL	Body	HVAC Control Module Manual																																																											
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																											
1	2012	Yukon XL	Body	Left Side Object Detection Module																																																											
1	2012	Yukon XL	Body	Lift Gate Module																																																											
1	2012	Yukon XL	Body	Memory Seat Module																																																											
1	2012	Yukon XL	Body	Park Assist Module																																																											
1	2012	Yukon XL	Body	Passenger Door Switch																																																											
1	2012	Yukon XL	Body	Passenger Presence System																																																											
1	2012	Yukon XL	Body	Radio																																																											
1	2012	Yukon XL	Body	Navigation Radio																																																											
1	2012	Yukon XL	Body	Rear Heated Seat Module																																																											
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																											
1	2012	Yukon XL	Body	Right Side Object Detection Module																																																											
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
1	2012	Yukon XL	Body	Theft Deterrent Module																																																											
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																								V																																		
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																								V																																		
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V	V	V																																																					
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																										
1	2013	Sierra	Chassis	Electronic Suspension Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Body	Amplifier (Bose)																																																										
1	2013	Sierra	Body	Body Control Module																																																										
1	2013	Sierra	Body	Body Control Module (aux.)																																																										
1	2013	Sierra	Body	Digital Radio Receiver																																																										
1	2013	Sierra	Body	Driver Door Switch																																																										
1	2013	Sierra	Body	HVAC Control Module Auto																																																										
1	2013	Sierra	Body	HVAC Control Module Manual																																																										
1	2013	Sierra	Body	Instrument Panel Cluster																																																										
1	2013	Sierra	Body	Memory Seat Module																																																										
1	2013	Sierra	Body	Park Assist Module																																																										
1	2013	Sierra	Body	Passenger Door Switch																																																										
1	2013	Sierra	Body	Passenger Presence System																																																										
1	2013	Sierra	Body	Radio																																																										
1	2013	Sierra	Body	Navigation Radio																																																										
1	2013	Sierra	Body	Rear Heated Seat Module																																																										
1	2013	Sierra	Body	Rear HVAC/RSA																																																										
1	2013	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2013	Sierra	Body	Theft Deterrent Module																																																										
1	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																											
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																											
1	2013	Sierra Hybrid	Body	Body Control Module																																																											
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																											
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																											
1	2013	Sierra Hybrid	Body	Driver Door Switch																																																											
1	2013	Sierra Hybrid	Body	Heated Seat Module																																																											
1	2013	Sierra Hybrid	Body	HVAC Control Module																																																											
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																											
1	2013	Sierra Hybrid	Body	Park Assist Module																																																											
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																																											
1	2013	Sierra Hybrid	Body	Passenger Presence System																																																											
1	2013	Sierra Hybrid	Body	Radio																																																											
1	2013	Sierra Hybrid	Body	Navigation Radio																																																											
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																											
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																											
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																											
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																											
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																											
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
1	2013	Yukon	Chassis	Electronic Brake Control Module																																																											
1	2013	Yukon	Chassis	Electronic Suspension Control																																																											
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Yukon	Body	Amplifier (Bose)																																																											
1	2013	Yukon	Body	Assist Step Controller																																																											
1	2013	Yukon	Body	Body Control Module																																																											
1	2013	Yukon	Body	Body Control Module (aux.)																																																											
1	2013	Yukon	Body	Digital Radio Receiver																																																											
1	2013	Yukon	Body	Driver Door Switch																																																											
1	2013	Yukon	Body	HVAC Control Module Auto																																																											
1	2013	Yukon	Body	HVAC Control Module Manual																																																											
1	2013	Yukon	Body	Instrument Panel Cluster																																																											
1	2013	Yukon	Body	Left Side Object Detection Module																																																											
1	2013	Yukon	Body	Lift Gate Module																																																											
1	2013	Yukon	Body	Memory Seat Module																																																											
1	2013	Yukon	Body	Park Assist Module																																																											
1	2013	Yukon	Body	Passenger Door Switch																																																											
1	2013	Yukon	Body	Passenger Presence System																																																											
1	2013	Yukon	Body	Radio																																																											
1	2013	Yukon	Body	Navigation Radio																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2013	Yukon	Body	Rear Heated Seat Module																																																											
1	2013	Yukon	Body	Rear HVAC/RSA																																																											
1	2013	Yukon	Body	Right Side Object Detection Module																																																											
1	2013	Yukon	Body	Supplemental Inflatable Restraint																																																											
1	2013	Yukon	Body	Theft Deterrent Module																																																											
1	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																											
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																											
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																											
1	2013	Yukon Hybrid	Body	Body Control Module																																																											
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																											
1	2013	Yukon Hybrid	Body	Driver Door Switch																																																											
1	2013	Yukon Hybrid	Body	Heated Seat Module																																																											
1	2013	Yukon Hybrid	Body	HVAC Control Module																																																											
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
1	2013	Yukon Hybrid	Body	Lift Gate Module																																																											
1	2013	Yukon Hybrid	Body	Park Assist Module																																																											
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																																											
1	2013	Yukon Hybrid	Body	Passenger Presence System																																																											
1	2013	Yukon Hybrid	Body	Radio																																																											
1	2013	Yukon Hybrid	Body	Navigation Radio																																																											
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																											
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																											
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon XL	Body	Amplifier (Bose)																																																										
1	2013	Yukon XL	Body	Assist Step Controller																																																										
1	2013	Yukon XL	Body	Body Control Module																																																										
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2013	Yukon XL	Body	Digital Radio Receiver																																																										
1	2013	Yukon XL	Body	Driver Door Switch																																																										
1	2013	Yukon XL	Body	HVAC Control Module Auto																																																										
1	2013	Yukon XL	Body	HVAC Control Module Manual																																																										
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																										
1	2013	Yukon XL	Body	Left Side Object Detection Module																																																										
1	2013	Yukon XL	Body	Lift Gate Module																																																										
1	2013	Yukon XL	Body	Memory Seat Module																																																										
1	2013	Yukon XL	Body	Park Assist Module																																																										
1	2013	Yukon XL	Body	Passenger Door Switch																																																										
1	2013	Yukon XL	Body	Passenger Presence System																																																										
1	2013	Yukon XL	Body	Radio																																																										
1	2013	Yukon XL	Body	Navigation Radio																																																										
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																										
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																										
1	2013	Yukon XL	Body	Right Side Object Detection Module																																																										
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
1	2013	Yukon XL	Body	Theft Deterrent Module																																																										
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2014	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2014	Sierra	Chassis	Parking Brake Control Module																																																										
1	2014	Sierra	Chassis	Power Steering Control Module																																																										
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2014	Sierra	Body	Body Control Module																																																										
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Sierra	Body	Passenger Presence Module																																																										
1	2014	Sierra	Body	Instrument Cluster																																																										
1	2014	Sierra	Body	Radio Control																																																										
1	2014	Sierra	Body	HVAC Control																																																										
1	2014	Sierra	Body	Radio																																																										
1	2014	Sierra	Body	Amplifier																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2014	Sierra	Body	Media Disc Player																																																									
1	2014	Sierra	Body	Human Machine Interface Control Module																																																									
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																									
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																									
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																									
1	2014	Sierra	Body	Parking Assist Control Module																																																									
1	2014	Sierra	Body	Frontview Camera Module																																																									
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																														
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																									
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																									
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																									
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																									
1	2014	Sierra HD	Chassis	Suspension Control Module																																																									
1	2014	Sierra HD	Body	Body Control Module																																																									
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2014	Sierra HD	Body	Instrument Cluster																																																									
1	2014	Sierra HD	Body	Base Radio																																																									
1	2014	Sierra HD	Body	Navigation Radio																																																									
1	2014	Sierra HD	Body	Uplevel Radio																																																									
1	2014	Sierra HD	Body	Amplifier																																																									
1	2014	Sierra HD	Body	Rear Audio Control Module																																																									
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																									
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																									
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																									
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																											V														
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																											V														
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																											V														
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																											V														
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																									
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																									
1	2014	Sierra HD	Body	Seat Memory Control Module																																																									
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																									
1	2014	Sierra HD	Body	Parking Assist Control Module																																																									
1	2014	Sierra HD	Body	Theft Deterrent Module																																																									
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																									
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																									
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																									
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2014	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2014	Yukon	Chassis	Parking Brake Control Module																																																									
1	2014	Yukon	Chassis	Suspension Control Module																																																									
1	2014	Yukon	Body	Body Control Module																																																									
1	2014	Yukon	Body	Auxiliary Body Control Module																																																									
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2014	Yukon	Body	Passenger Presence Module																																																									
1	2014	Yukon	Body	Instrument Cluster																																																									
1	2014	Yukon	Body	Base Radio																																																									
1	2014	Yukon	Body	Navigation Radio																																																									
1	2014	Yukon	Body	Uplevel Radio																																																									
1	2014	Yukon	Body	Amplifier																																																									
1	2014	Yukon	Body	Rear Audio Control Module																																																									
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																																									
1	2014	Yukon	Body	Personal Audio Link Control Module																																																									
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																									
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																										V															
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																										V															
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																									
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																									
1	2014	Yukon	Body	Liftgate Control Module																																																									
1	2014	Yukon	Body	Seat Memory Control Module																																																									
1	2014	Yukon	Body	Rear Seat Heating Control Module																																																									
1	2014	Yukon	Body	Assist Step Control Module																																																									
1	2014	Yukon	Body	Right Side Object Detection Control Module																																																									
1	2014	Yukon	Body	Left Side Object Detection Control Module																																																									
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																																									
1	2014	Yukon	Body	Parking Assist Control Module																																																									
1	2014	Yukon	Body	Theft Deterrent Module																																																									
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																									
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																									
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																									
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																									
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																									
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																									
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																																									
1	2014	Yukon XL	Chassis	Suspension Control Module																																																									
1	2014	Yukon XL	Body	Body Control Module																																																									
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																																									
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2014	Yukon XL	Body	Passenger Presence Module																																																									
1	2014	Yukon XL	Body	Instrument Cluster																																																									
1	2014	Yukon XL	Body	Base Radio																																																									
1	2014	Yukon XL	Body	Navigation Radio																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2014	Yukon XL	Body	Uplevel Radio																																																										
1	2014	Yukon XL	Body	Amplifier																																																										
1	2014	Yukon XL	Body	Rear Audio Control Module																																																										
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																										
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																																										
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																										V																
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																										V																
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Yukon XL	Body	Liftgate Control Module																																																										
1	2014	Yukon XL	Body	Seat Memory Control Module																																																										
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																										
1	2014	Yukon XL	Body	Assist Step Control Module																																																										
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																										
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																										
1	2014	Yukon XL	Body	Parking Assist Control Module																																																										
1	2014	Yukon XL	Body	Theft Deterrent Module																																																										
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																															
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																										
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Sierra	Chassis	Electronic Brake Control Module																																																										
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Sierra	Chassis	Power Steering Control Module																																																										
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Sierra	Chassis	Suspension Control Module																																																										
1	2015	Sierra	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Sierra	Body	Passenger Presence Module																																																										
1	2015	Sierra	Body	Instrument Cluster																																																										
1	2015	Sierra	Body	Radio Controls																																																										
1	2015	Sierra	Body	HVAC Controls																																																										
1	2015	Sierra	Body	Radio																																																										
1	2015	Sierra	Body	Amplifier																																																										
1	2015	Sierra	Body	Media Disc Player																																																										
1	2015	Sierra	Body	Human Machine Interface Control Module																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2015	Sierra	Body	Parking Assist Control Module																																																										
1	2015	Sierra	Body	Frontview Camera Module																																																										
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																										
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																										
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																										
1	2015	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Yukon	Chassis	Parking Brake Control Module																																																										
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	Yukon	Chassis	Power Steering Control Module																																																										
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Yukon	Chassis	Suspension Control Module																																																										
1	2015	Yukon	Body	Body Control Module																																																										
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Yukon	Body	Passenger Presence Module																																																										
1	2015	Yukon	Body	Instrument Cluster																																																										
1	2015	Yukon	Body	Radio Controls																																																										
1	2015	Yukon	Body	HVAC Controls																																																										
1	2015	Yukon	Body	Radio																																																										
1	2015	Yukon	Body	Amplifier																																																										
1	2015	Yukon	Body	Media Disc Player																																																										
1	2015	Yukon	Body	Human Machine Interface Control Module																																																										
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2015	Yukon	Body	HVAC Control Module																																																											
1	2015	Yukon	Body	Liftgate Control Module																																																												
1	2015	Yukon	Body	Keyless Entry Control Module																																																												
1	2015	Yukon	Body	Assist Step Control Module																																																												
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																												
1	2015	Yukon	Body	Parking Assist Control Module																																																												
1	2015	Yukon	Body	Frontview Camera Module																																																												
1	2015	Yukon	Body	Steering Column Lock Control Module																																																												
1	2015	Yukon	Body	Battery Energy Control Module																																																												
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																												
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																												
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																												
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																												
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																												
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																												
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																												
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																												
1	2015	Yukon XL	Chassis	Power Steering Control Module																																																												
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2015	Yukon XL	Chassis	Suspension Control Module																																																												
1	2015	Yukon XL	Body	Body Control Module																																																												
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2015	Yukon XL	Body	Passenger Presence Module																																																												
1	2015	Yukon XL	Body	Instrument Cluster																																																												
1	2015	Yukon XL	Body	Radio Controls																																																												
1	2015	Yukon XL	Body	HVAC Controls																																																												
1	2015	Yukon XL	Body	Radio																																																												
1	2015	Yukon XL	Body	Amplifier																																																												
1	2015	Yukon XL	Body	Media Disc Player																																																												
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																												
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																												
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																												
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2015	Yukon XL	Body	HVAC Control Module																																																												
1	2015	Yukon XL	Body	Liftgate Control Module																																																												
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																												
1	2015	Yukon XL	Body	Assist Step Control Module																																																												
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																												
1	2015	Yukon XL	Body	Parking Assist Control Module																																																												
1	2015	Yukon XL	Body	Frontview Camera Module																																																												
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																												
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																											
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																											
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																											
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																											
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																											
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																												
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2016	Sierra	Chassis	Electronic Brake Control Module																																																											
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																											
1	2016	Sierra	Chassis	Parking Brake Control Module																																																											
1	2016	Sierra	Chassis	Power Steering Control Module																																																											
1	2016	Sierra	Chassis	Power Steering Control Module																																																											
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	Sierra	Chassis	Suspension Control Module																																																											
1	2016	Sierra	Body	Body Control Module																																																											
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2016	Sierra	Body	Passenger Presence Module																																																											
1	2016	Sierra	Body	Instrument Cluster																																																											
1	2016	Sierra	Body	Radio Controls																																																											
1	2016	Sierra	Body	HVAC Controls																																																											
1	2016	Sierra	Body	Radio (IO3)																																																											
1	2016	Sierra	Body	Radio (IOB)																																																											
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																											
1	2016	Sierra	Body	Amplifier																																																											
1	2016	Sierra	Body	Media Disc Player																																																											
1	2016	Sierra	Body	Human Machine Interface Control Module																																																											
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																											
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																											
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																											
1	2016	Sierra	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2016	Sierra	Body	Frontview Camera Module																																																										
1	2016	Sierra	Body	Frontview Camera Module																																																										
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2016	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Yukon	Chassis	Parking Brake Control Module																																																										
1	2016	Yukon	Chassis	Power Steering Control Module																																																										
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Yukon	Chassis	Suspension Control Module																																																										
1	2016	Yukon	Body	Body Control Module																																																										
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2016	Yukon	Body	Passenger Presence Module																																																										
1	2016	Yukon	Body	Instrument Cluster																																																										
1	2016	Yukon	Body	Radio Controls																																																										
1	2016	Yukon	Body	HVAC Controls																																																										
1	2016	Yukon	Body	Radio																																																										
1	2016	Yukon	Body	Amplifier																																																										
1	2016	Yukon	Body	Media Disc Player																																																										
1	2016	Yukon	Body	Human Machine Interface Control Module																																																										
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																										
1	2016	Yukon	Body	HVAC Control Module																																																										
1	2016	Yukon	Body	Liftgate Control Module																																																										
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																										
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																										
1	2016	Yukon	Body	Keyless Entry Control Module																																																										
1	2016	Yukon	Body	Assist Step Control Module																																																										
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2016	Yukon	Body	Parking Assist Control Module																																																										
1	2016	Yukon	Body	Frontview Camera Module																																																										
1	2016	Yukon	Body	Steering Column Lock Control Module																																																										
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2016	Yukon XL	Chassis	Power Steering Control Module																																																										
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2016	Yukon XL	Chassis	Suspension Control Module																																																										
1	2016	Yukon XL	Body	Body Control Module																																																										
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
1	2016	Yukon XL	Body	Passenger Presence Module																																																												
1	2016	Yukon XL	Body	Instrument Cluster																																																												
1	2016	Yukon XL	Body	Radio Controls																																																												
1	2016	Yukon XL	Body	HVAC Controls																																																												
1	2016	Yukon XL	Body	Radio																																																												
1	2016	Yukon XL	Body	Amplifier																																																												
1	2016	Yukon XL	Body	Media Disc Player																																																												
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																												
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																												
1	2016	Yukon XL	Body	HVAC Control Module																																																												
1	2016	Yukon XL	Body	Liftgate Control Module																																																												
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																												
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																												
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																												
1	2016	Yukon XL	Body	Assist Step Control Module																																																												
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																												
1	2016	Yukon XL	Body	Parking Assist Control Module																																																												
1	2016	Yukon XL	Body	Frontview Camera Module																																																												
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																												
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																							V																																					
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																							
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V	V	V																																																							
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																											
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																											
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
2	2011	Sierra	Chassis	Electronic Suspension Control																																																											
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																											
2	2011	Sierra	Body	Amplifier (Bose)																																																											
2	2011	Sierra	Body	Body Control Module																																																											
2	2011	Sierra	Body	Body Control Module (aux.)																																																											
2	2011	Sierra	Body	Digital Radio Receiver																																																											
2	2011	Sierra	Body	Driver Door Switch																																																											
2	2011	Sierra	Body	HVAC Control Module Auto																																																											
2	2011	Sierra	Body	HVAC Control Module Manual																																																											
2	2011	Sierra	Body	Instrument Panel Cluster																																																											
2	2011	Sierra	Body	Memory Seat Module																																																											
2	2011	Sierra	Body	Park Assist Module																																																											
2	2011	Sierra	Body	Passenger Door Switch																																																											
2	2011	Sierra	Body	Passenger Presence System																																																											
2	2011	Sierra	Body	Radio																																																											
2	2011	Sierra	Body	Rear Heated Seat Module																																																											
2	2011	Sierra	Body	Rear HVAC/RSA																																																											
2	2011	Sierra	Body	Supplemental Inflatable Restraint																																																											
2	2011	Sierra	Body	Theft Deterrent Module																																																											
2	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																											
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																											
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																											
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																											
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																											
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																											
2	2011	Sierra Hybrid	Body	Body Control Module																																																											
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																											
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																											
2	2011	Sierra Hybrid	Body	Driver Door Switch																																																											
2	2011	Sierra Hybrid	Body	Heated Seat Module																																																											
2	2011	Sierra Hybrid	Body	HVAC Control Module																																																											
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																											
2	2011	Sierra Hybrid	Body	Park Assist Module																																																											
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																																											
2	2011	Sierra Hybrid	Body	Passenger Presence System																																																											
2	2011	Sierra Hybrid	Body	Radio																																																											
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																											
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2011	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2011	Yukon	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																										
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon	Body	Amplifier (Bose)																																																										
2	2011	Yukon	Body	Assist Step Controller																																																										
2	2011	Yukon	Body	Body Control Module																																																										
2	2011	Yukon	Body	Body Control Module (aux.)																																																										
2	2011	Yukon	Body	Digital Radio Receiver																																																										
2	2011	Yukon	Body	Driver Door Switch																																																										
2	2011	Yukon	Body	HVAC Control Module Auto																																																										
2	2011	Yukon	Body	HVAC Control Module Manual																																																										
2	2011	Yukon	Body	Instrument Panel Cluster																																																										
2	2011	Yukon	Body	Left Side Object Detection Module																																																										
2	2011	Yukon	Body	Lift Gate Module																																																										
2	2011	Yukon	Body	Memory Seat Module																																																										
2	2011	Yukon	Body	Park Assist Module																																																										
2	2011	Yukon	Body	Passenger Door Switch																																																										
2	2011	Yukon	Body	Passenger Presence System																																																										
2	2011	Yukon	Body	Radio																																																									
2	2011	Yukon	Body	Rear Heated Seat Module																																																										
2	2011	Yukon	Body	Rear HVAC/RSA																																																										
2	2011	Yukon	Body	Right Side Object Detection Module																																																										
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2011	Yukon	Body	Theft Deterrent Module																																																										
2	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																												
2	2011	Yukon Hybrid	Body	Body Control Module																																																												
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																												
2	2011	Yukon Hybrid	Body	Driver Door Switch																																																												
2	2011	Yukon Hybrid	Body	Heated Seat Module																																																												
2	2011	Yukon Hybrid	Body	HVAC Control Module																																																												
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
2	2011	Yukon Hybrid	Body	Lift Gate Module																																																												
2	2011	Yukon Hybrid	Body	Park Assist Module																																																												
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																																												
2	2011	Yukon Hybrid	Body	Passenger Presence System																																																												
2	2011	Yukon Hybrid	Body	Radio																																																												
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																												
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																												
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																												
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																												
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																												
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																												
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																												
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
2	2011	Yukon XL	Body	Amplifier (Bose)																																																												
2	2011	Yukon XL	Body	Assist Step Controller																																																												
2	2011	Yukon XL	Body	Body Control Module																																																												
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																												
2	2011	Yukon XL	Body	Digital Radio Receiver																																																												
2	2011	Yukon XL	Body	Driver Door Switch																																																												
2	2011	Yukon XL	Body	HVAC Control Module Auto																																																												
2	2011	Yukon XL	Body	HVAC Control Module Manual																																																												
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																												
2	2011	Yukon XL	Body	Left Side Object Detection Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2011	Yukon XL	Body	Lift Gate Module																																																											
2	2011	Yukon XL	Body	Memory Seat Module																																																												
2	2011	Yukon XL	Body	Park Assist Module																																																												
2	2011	Yukon XL	Body	Passenger Door Switch																																																												
2	2011	Yukon XL	Body	Passenger Presence System																																																												
2	2011	Yukon XL	Body	Radio																																																												
2	2011	Yukon XL	Body	Rear Heated Seat Module																																																												
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																												
2	2011	Yukon XL	Body	Right Side Object Detection Module																																																												
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
2	2011	Yukon XL	Body	Theft Deterrent Module																																																												
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																							V																																					
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																						
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V	V	V																																																						
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																												
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
2	2012	Sierra	Chassis	Electronic Suspension Control																																																												
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																												
2	2012	Sierra	Body	Amplifier (Bose)																																																												
2	2012	Sierra	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2012	Sierra	Body	Body Control Module (aux.)																																																										
2	2012	Sierra	Body	Digital Radio Receiver																																																										
2	2012	Sierra	Body	Driver Door Switch																																																										
2	2012	Sierra	Body	HVAC Control Module Auto																																																										
2	2012	Sierra	Body	HVAC Control Module Manual																																																										
2	2012	Sierra	Body	Instrument Panel Cluster																																																										
2	2012	Sierra	Body	Memory Seat Module																																																										
2	2012	Sierra	Body	Park Assist Module																																																										
2	2012	Sierra	Body	Passenger Door Switch																																																										
2	2012	Sierra	Body	Passenger Presence System																																																										
2	2012	Sierra	Body	Radio																																																										
2	2012	Sierra	Body	Navigation Radio																																																										
2	2012	Sierra	Body	Rear Heated Seat Module																																																										
2	2012	Sierra	Body	Rear HVAC/RSA																																																										
2	2012	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra	Body	Theft Deterrent Module																																																										
2	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Sierra Hybrid	Body	Body Control Module																																																										
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2012	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2012	Sierra Hybrid	Body	Park Assist Module																																																										
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2012	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2012	Sierra Hybrid	Body	Radio																																																										
2	2012	Sierra Hybrid	Body	Navigation Radio																																																										
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2012	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2012	Yukon	Chassis	Electronic Suspension Control																																																										
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																										
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Yukon	Body	Amplifier (Bose)																																																										
2	2012	Yukon	Body	Assist Step Controller																																																										
2	2012	Yukon	Body	Body Control Module																																																										
2	2012	Yukon	Body	Body Control Module (aux.)																																																										
2	2012	Yukon	Body	Digital Radio Receiver																																																										
2	2012	Yukon	Body	Driver Door Switch																																																										
2	2012	Yukon	Body	HVAC Control Module Auto																																																										
2	2012	Yukon	Body	HVAC Control Module Manual																																																										
2	2012	Yukon	Body	Instrument Panel Cluster																																																										
2	2012	Yukon	Body	Left Side Object Detection Module																																																										
2	2012	Yukon	Body	Lift Gate Module																																																										
2	2012	Yukon	Body	Memory Seat Module																																																										
2	2012	Yukon	Body	Park Assist Module																																																										
2	2012	Yukon	Body	Passenger Door Switch																																																										
2	2012	Yukon	Body	Passenger Presence System																																																										
2	2012	Yukon	Body	Radio																																																										
2	2012	Yukon	Body	Navigation Radio																																																										
2	2012	Yukon	Body	Rear Heated Seat Module																																																										
2	2012	Yukon	Body	Rear HVAC/RSA																																																										
2	2012	Yukon	Body	Right Side Object Detection Module																																																										
2	2012	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2012	Yukon	Body	Theft Deterrent Module																																																										
2	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2012	Yukon Hybrid	Body	Body Control Module																																																										
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Yukon Hybrid	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2012	Yukon Hybrid	Body	Heated Seat Module																																																											
2	2012	Yukon Hybrid	Body	HVAC Control Module																																																											
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
2	2012	Yukon Hybrid	Body	Lift Gate Module																																																											
2	2012	Yukon Hybrid	Body	Park Assist Module																																																											
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																																											
2	2012	Yukon Hybrid	Body	Passenger Presence System																																																											
2	2012	Yukon Hybrid	Body	Radio																																																											
2	2012	Yukon Hybrid	Body	Navigation Radio																																																											
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																											
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																											
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																											
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
2	2012	Yukon XL	Body	Amplifier (Bose)																																																											
2	2012	Yukon XL	Body	Assist Step Controller																																																											
2	2012	Yukon XL	Body	Body Control Module																																																											
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																											
2	2012	Yukon XL	Body	Digital Radio Receiver																																																											
2	2012	Yukon XL	Body	Driver Door Switch																																																											
2	2012	Yukon XL	Body	HVAC Control Module Auto																																																											
2	2012	Yukon XL	Body	HVAC Control Module Manual																																																											
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																											
2	2012	Yukon XL	Body	Left Side Object Detection Module																																																											
2	2012	Yukon XL	Body	Lift Gate Module																																																											
2	2012	Yukon XL	Body	Memory Seat Module																																																											
2	2012	Yukon XL	Body	Park Assist Module																																																											
2	2012	Yukon XL	Body	Passenger Door Switch																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2012	Yukon XL	Body	Passenger Presence System																																																											
2	2012	Yukon XL	Body	Radio																																																											
2	2012	Yukon XL	Body	Navigation Radio																																																											
2	2012	Yukon XL	Body	Rear Heated Seat Module																																																											
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																											
2	2012	Yukon XL	Body	Right Side Object Detection Module																																																											
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
2	2012	Yukon XL	Body	Theft Deterrent Module																																																											
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																							V																																				
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																							V																																				
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																											
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module	V	V	V	V	V																																																						
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																											
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																											
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																											
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																											
2	2013	Sierra	Chassis	Electronic Suspension Control																																																											
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
2	2013	Sierra	Body	Amplifier (Bose)																																																											
2	2013	Sierra	Body	Body Control Module																																																											
2	2013	Sierra	Body	Body Control Module (aux.)																																																											
2	2013	Sierra	Body	Digital Radio Receiver																																																											
2	2013	Sierra	Body	Driver Door Switch																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2013	Sierra	Body	HVAC Control Module Auto																																																										
2	2013	Sierra	Body	HVAC Control Module Manual																																																										
2	2013	Sierra	Body	Instrument Panel Cluster																																																										
2	2013	Sierra	Body	Memory Seat Module																																																										
2	2013	Sierra	Body	Park Assist Module																																																										
2	2013	Sierra	Body	Passenger Door Switch																																																										
2	2013	Sierra	Body	Passenger Presence System																																																										
2	2013	Sierra	Body	Radio																																																										
2	2013	Sierra	Body	Navigation Radio																																																										
2	2013	Sierra	Body	Rear Heated Seat Module																																																										
2	2013	Sierra	Body	Rear HVAC/RSA																																																										
2	2013	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2013	Sierra	Body	Theft Deterrent Module																																																										
2	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Sierra Hybrid	Body	Body Control Module																																																										
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2013	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2013	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2013	Sierra Hybrid	Body	Park Assist Module																																																										
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2013	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2013	Sierra Hybrid	Body	Radio																																																										
2	2013	Sierra Hybrid	Body	Navigation Radio																																																										
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2013	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Body	Amplifier (Bose)																																																										
2	2013	Yukon	Body	Assist Step Controller																																																										
2	2013	Yukon	Body	Body Control Module																																																										
2	2013	Yukon	Body	Body Control Module (aux.)																																																										
2	2013	Yukon	Body	Digital Radio Receiver																																																										
2	2013	Yukon	Body	Driver Door Switch																																																										
2	2013	Yukon	Body	HVAC Control Module Auto																																																										
2	2013	Yukon	Body	HVAC Control Module Manual																																																										
2	2013	Yukon	Body	Instrument Panel Cluster																																																										
2	2013	Yukon	Body	Left Side Object Detection Module																																																										
2	2013	Yukon	Body	Lift Gate Module																																																										
2	2013	Yukon	Body	Memory Seat Module																																																										
2	2013	Yukon	Body	Park Assist Module																																																										
2	2013	Yukon	Body	Passenger Door Switch																																																										
2	2013	Yukon	Body	Passenger Presence System																																																										
2	2013	Yukon	Body	Radio																																																										
2	2013	Yukon	Body	Navigation Radio																																																										
2	2013	Yukon	Body	Rear Heated Seat Module																																																										
2	2013	Yukon	Body	Rear HVAC/RSA																																																										
2	2013	Yukon	Body	Right Side Object Detection Module																																																										
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2013	Yukon	Body	Theft Deterrent Module																																																										
2	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2013	Yukon Hybrid	Body	Body Control Module																																																										
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Yukon Hybrid	Body	Driver Door Switch																																																										
2	2013	Yukon Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2013	Yukon Hybrid	Body	HVAC Control Module																																																											
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
2	2013	Yukon Hybrid	Body	Lift Gate Module																																																											
2	2013	Yukon Hybrid	Body	Park Assist Module																																																											
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																																											
2	2013	Yukon Hybrid	Body	Passenger Presence System																																																											
2	2013	Yukon Hybrid	Body	Radio																																																											
2	2013	Yukon Hybrid	Body	Navigation Radio																																																											
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																											
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																											
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																											
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																											
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																											
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																											
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																											
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																											
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																											
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																											
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																											
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																											
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
2	2013	Yukon XL	Body	Amplifier (Bose)																																																											
2	2013	Yukon XL	Body	Assist Step Controller																																																											
2	2013	Yukon XL	Body	Body Control Module																																																											
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																											
2	2013	Yukon XL	Body	Digital Radio Receiver																																																											
2	2013	Yukon XL	Body	Driver Door Switch																																																											
2	2013	Yukon XL	Body	HVAC Control Module Auto																																																											
2	2013	Yukon XL	Body	HVAC Control Module Manual																																																											
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																											
2	2013	Yukon XL	Body	Left Side Object Detection Module																																																											
2	2013	Yukon XL	Body	Lift Gate Module																																																											
2	2013	Yukon XL	Body	Memory Seat Module																																																											
2	2013	Yukon XL	Body	Park Assist Module																																																											
2	2013	Yukon XL	Body	Passenger Door Switch																																																											
2	2013	Yukon XL	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2013	Yukon XL	Body	Radio																																																												
2	2013	Yukon XL	Body	Navigation Radio																																																												
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																												
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																												
2	2013	Yukon XL	Body	Right Side Object Detection Module																																																												
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
2	2013	Yukon XL	Body	Theft Deterrent Module																																																												
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																												
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2014	Sierra	Chassis	Electronic Brake Control Module																																																												
2	2014	Sierra	Chassis	Parking Brake Control Module																																																												
2	2014	Sierra	Chassis	Power Steering Control Module																																																												
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2014	Sierra	Body	Body Control Module																																																												
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2014	Sierra	Body	Passenger Presence Module																																																												
2	2014	Sierra	Body	Instrument Cluster																																																												
2	2014	Sierra	Body	Radio Control																																																												
2	2014	Sierra	Body	HVAC Control																																																												
2	2014	Sierra	Body	Radio																																																												
2	2014	Sierra	Body	Amplifier																																																												
2	2014	Sierra	Body	Media Disc Player																																																												
2	2014	Sierra	Body	Human Machine Interface Control Module																																																												
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																												
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
2	2014	Sierra	Body	Parking Assist Control Module																																																												
2	2014	Sierra	Body	Frontview Camera Module																																																												
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																	
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																												
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																												
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																												
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2014	Sierra HD	Chassis	Suspension Control Module																																																									
2	2014	Sierra HD	Body	Body Control Module																																																									
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2014	Sierra HD	Body	Instrument Cluster																																																									
2	2014	Sierra HD	Body	Base Radio																																																									
2	2014	Sierra HD	Body	Navigation Radio																																																									
2	2014	Sierra HD	Body	Uplevel Radio																																																									
2	2014	Sierra HD	Body	Amplifier																																																									
2	2014	Sierra HD	Body	Rear Audio Control Module																																																									
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																									
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																									
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																									
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																											V														
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																											V														
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																											V														
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																											V														
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																									
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																									
2	2014	Sierra HD	Body	Seat Memory Control Module																																																									
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																									
2	2014	Sierra HD	Body	Parking Assist Control Module																																																									
2	2014	Sierra HD	Body	Theft Deterrent Module																																																									
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																									
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																									
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																									
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																									
2	2014	Yukon	Chassis	Parking Brake Control Module																																																									
2	2014	Yukon	Chassis	Suspension Control Module																																																									
2	2014	Yukon	Body	Body Control Module																																																									
2	2014	Yukon	Body	Auxiliary Body Control Module																																																									
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2014	Yukon	Body	Passenger Presence Module																																																									
2	2014	Yukon	Body	Instrument Cluster																																																									
2	2014	Yukon	Body	Base Radio																																																									
2	2014	Yukon	Body	Navigation Radio																																																									
2	2014	Yukon	Body	Uplevel Radio																																																									
2	2014	Yukon	Body	Amplifier																																																									
2	2014	Yukon	Body	Rear Audio Control Module																																																									
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																									
2	2014	Yukon	Body	Personal Audio Link Control Module																																																									
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																									
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																											V														
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																											V														
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Yukon	Body	Liftgate Control Module																																																											
2	2014	Yukon	Body	Seat Memory Control Module																																																											
2	2014	Yukon	Body	Rear Seat Heating Control Module																																																											
2	2014	Yukon	Body	Assist Step Control Module																																																											
2	2014	Yukon	Body	Right Side Object Detection Control Module																																																											
2	2014	Yukon	Body	Left Side Object Detection Control Module																																																											
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																											
2	2014	Yukon	Body	Parking Assist Control Module																																																											
2	2014	Yukon	Body	Theft Deterrent Module																																																											
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																											
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																											
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																											
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																											
2	2014	Yukon XL	Chassis	Suspension Control Module																																																											
2	2014	Yukon XL	Body	Body Control Module																																																											
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																											
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2014	Yukon XL	Body	Passenger Presence Module																																																											
2	2014	Yukon XL	Body	Instrument Cluster																																																											
2	2014	Yukon XL	Body	Base Radio																																																											
2	2014	Yukon XL	Body	Navigation Radio																																																											
2	2014	Yukon XL	Body	Uplevel Radio																																																											
2	2014	Yukon XL	Body	Amplifier																																																											
2	2014	Yukon XL	Body	Rear Audio Control Module																																																											
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																											
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																											
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																											
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																										V																
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																										V																
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																											
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																											
2	2014	Yukon XL	Body	Liftgate Control Module																																																											
2	2014	Yukon XL	Body	Seat Memory Control Module																																																											
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																											
2	2014	Yukon XL	Body	Assist Step Control Module																																																											
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																											
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																											
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																											
2	2014	Yukon XL	Body	Parking Assist Control Module																																																											
2	2014	Yukon XL	Body	Theft Deterrent Module																																																											
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																												
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2015	Sierra	Chassis	Electronic Brake Control Module																																																												
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																												
2	2015	Sierra	Chassis	Power Steering Control Module																																																												
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2015	Sierra	Chassis	Suspension Control Module																																																												
2	2015	Sierra	Body	Body Control Module																																																												
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2015	Sierra	Body	Passenger Presence Module																																																												
2	2015	Sierra	Body	Instrument Cluster																																																												
2	2015	Sierra	Body	Radio Controls																																																												
2	2015	Sierra	Body	HVAC Controls																																																												
2	2015	Sierra	Body	Radio																																																											
2	2015	Sierra	Body	Amplifier																																																											
2	2015	Sierra	Body	Media Disc Player																																																											
2	2015	Sierra	Body	Human Machine Interface Control Module																																																											
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																											
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
2	2015	Sierra	Body	Parking Assist Control Module																																																											
2	2015	Sierra	Body	Frontview Camera Module																																																											
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																											
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																											
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																											
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																											
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																											
2	2015	Yukon	Chassis	Electronic Brake Control Module																																																											
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																											
2	2015	Yukon	Chassis	Parking Brake Control Module																																																											
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																											
2	2015	Yukon	Chassis	Power Steering Control Module																																																											
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2015	Yukon	Chassis	Suspension Control Module																																																											
2	2015	Yukon	Body	Body Control Module																																																											
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2015	Yukon	Body	Passenger Presence Module																																																											
2	2015	Yukon	Body	Instrument Cluster																																																											
2	2015	Yukon	Body	Radio Controls																																																											
2	2015	Yukon	Body	HVAC Controls																																																											
2	2015	Yukon	Body	Radio																																																											
2	2015	Yukon	Body	Amplifier																																																											
2	2015	Yukon	Body	Media Disc Player																																																											
2	2015	Yukon	Body	Human Machine Interface Control Module																																																											
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																											
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																											
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2015	Yukon	Body	HVAC Control Module																																																											
2	2015	Yukon	Body	Liftgate Control Module																																																											
2	2015	Yukon	Body	Keyless Entry Control Module																																																											
2	2015	Yukon	Body	Assist Step Control Module																																																											
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																											
2	2015	Yukon	Body	Parking Assist Control Module																																																											
2	2015	Yukon	Body	Frontview Camera Module																																																											
2	2015	Yukon	Body	Steering Column Lock Control Module																																																											
2	2015	Yukon	Body	Battery Energy Control Module																																																											
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																											
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																											
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																											
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																											
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																											
2	2015	Yukon XL	Chassis	Power Steering Control Module																																																											
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2015	Yukon XL	Chassis	Suspension Control Module																																																											
2	2015	Yukon XL	Body	Body Control Module																																																											
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2015	Yukon XL	Body	Passenger Presence Module																																																											
2	2015	Yukon XL	Body	Instrument Cluster																																																											
2	2015	Yukon XL	Body	Radio Controls																																																											
2	2015	Yukon XL	Body	HVAC Controls																																																											
2	2015	Yukon XL	Body	Radio																																																											
2	2015	Yukon XL	Body	Amplifier																																																											
2	2015	Yukon XL	Body	Media Disc Player																																																											
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																											
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																											
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																											
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2015	Yukon XL	Body	HVAC Control Module																																																											
2	2015	Yukon XL	Body	Liftgate Control Module																																																											
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																											
2	2015	Yukon XL	Body	Assist Step Control Module																																																											
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																											
2	2015	Yukon XL	Body	Parking Assist Control Module																																																											
2	2015	Yukon XL	Body	Frontview Camera Module																																																											
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																											
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																											
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																											
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																											
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																											
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																															
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2016	Sierra	Chassis	Electronic Brake Control Module																																																											
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																											
2	2016	Sierra	Chassis	Parking Brake Control Module																																																											
2	2016	Sierra	Chassis	Power Steering Control Module																																																											
2	2016	Sierra	Chassis	Power Steering Control Module																																																											
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2016	Sierra	Chassis	Suspension Control Module																																																											
2	2016	Sierra	Body	Body Control Module																																																											
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2016	Sierra	Body	Passenger Presence Module																																																											
2	2016	Sierra	Body	Instrument Cluster																																																											
2	2016	Sierra	Body	Radio Controls																																																											
2	2016	Sierra	Body	HVAC Controls																																																											
2	2016	Sierra	Body	Radio (IO3)																																																											
2	2016	Sierra	Body	Radio (IOB)																																																											
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																											
2	2016	Sierra	Body	Amplifier																																																											
2	2016	Sierra	Body	Media Disc Player																																																											
2	2016	Sierra	Body	Human Machine Interface Control Module																																																											
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																											
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																											
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																											
2	2016	Sierra	Body	Parking Assist Control Module																																																											
2	2016	Sierra	Body	Frontview Camera Module																																																											
2	2016	Sierra	Body	Frontview Camera Module																																																											
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2016	Yukon	Chassis	Electronic Brake Control Module																																																											
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																											
2	2016	Yukon	Chassis	Parking Brake Control Module																																																											
2	2016	Yukon	Chassis	Power Steering Control Module																																																											
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2016	Yukon	Chassis	Suspension Control Module																																																											
2	2016	Yukon	Body	Body Control Module																																																											
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2016	Yukon	Body	Passenger Presence Module																																																											
2	2016	Yukon	Body	Instrument Cluster																																																											
2	2016	Yukon	Body	Radio Controls																																																											
2	2016	Yukon	Body	HVAC Controls																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
2	2016	Yukon	Body	Radio																																																											
2	2016	Yukon	Body	Amplifier																																																											
2	2016	Yukon	Body	Media Disc Player																																																											
2	2016	Yukon	Body	Human Machine Interface Control Module																																																											
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																											
2	2016	Yukon	Body	HVAC Control Module																																																											
2	2016	Yukon	Body	Liftgate Control Module																																																											
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																											
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																											
2	2016	Yukon	Body	Keyless Entry Control Module																																																											
2	2016	Yukon	Body	Assist Step Control Module																																																											
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																											
2	2016	Yukon	Body	Parking Assist Control Module																																																											
2	2016	Yukon	Body	Frontview Camera Module																																																											
2	2016	Yukon	Body	Steering Column Lock Control Module																																																											
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																											
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																											
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																											
2	2016	Yukon XL	Chassis	Power Steering Control Module																																																											
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2016	Yukon XL	Chassis	Suspension Control Module																																																											
2	2016	Yukon XL	Body	Body Control Module																																																											
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2016	Yukon XL	Body	Passenger Presence Module																																																											
2	2016	Yukon XL	Body	Instrument Cluster																																																											
2	2016	Yukon XL	Body	Radio Controls																																																											
2	2016	Yukon XL	Body	HVAC Controls																																																											
2	2016	Yukon XL	Body	Radio																																																											
2	2016	Yukon XL	Body	Amplifier																																																											
2	2016	Yukon XL	Body	Media Disc Player																																																											
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																											
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																											
2	2016	Yukon XL	Body	HVAC Control Module																																																											
2	2016	Yukon XL	Body	Liftgate Control Module																																																											
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																											
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																											
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																											
2	2016	Yukon XL	Body	Assist Step Control Module																																																											
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																											
2	2016	Yukon XL	Body	Parking Assist Control Module																																																											
2	2016	Yukon XL	Body	Frontview Camera Module																																																											
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																											
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																													
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																													
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																													
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																													
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																													
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																													
5	2011	ALL	Chassis	Electronic Brake Control Module																																																														
5	2011	ALL	Body	Body Control Module																																																														
5	2011	ALL	Body	Digital Radio Receiver																																																														
5	2011	ALL	Body	Generator Battery Control Module																																																														
5	2011	ALL	Body	Instrument Panel Cluster																																																														
5	2011	ALL	Body	Passenger Presence System																																																														
5	2011	ALL	Body	Personal Audio Link Module																																																														
5	2011	ALL	Body	Base Radio																																																														
5	2011	ALL	Body	Uplevel Radio																																																														
5	2011	ALL	Body	Supplemental Inflatable Restraint																																																														
5	2011	ALL	Body	Theft Deterrent Module																																																														
5	2011	ALL	Body	Vehicle Comm. Interface Module																																																														
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																													
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																													
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																													
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																													
5	2012	ALL	Chassis	Electronic Brake Control Module																																																													
5	2012	ALL	Body	Body Control Module																																																														
5	2012	ALL	Body	Digital Radio Receiver																																																														
5	2012	ALL	Body	Generator Battery Control Module																																																														
5	2012	ALL	Body	Instrument Panel Cluster																																																														
5	2012	ALL	Body	Passenger Presence System																																																														
5	2012	ALL	Body	Personal Audio Link Module																																																														
5	2012	ALL	Body	Base Radio																																																														
5	2012	ALL	Body	Uplevel Radio																																																														
5	2012	ALL	Body	Supplemental Inflatable Restraint																																																														
5	2012	ALL	Body	Theft Deterrent Module																																																														
5	2012	ALL	Body	Vehicle Comm. Interface Module																																																														
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																														
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																														
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																														
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																													
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																													
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
5	2015	Canyon	Powertrain	Chassis Control Module																																																														
5	2015	Canyon	Powertrain	Transfer Case Control Module																																																														
5	2015	Canyon	Chassis	Electronic Brake Control Module																																																														
5	2015	Canyon	Chassis	Power Steering Control Module																																																														
5	2015	Canyon	Body	Body Control Module																																																														

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
5	2015	Canyon	Body	Passenger Presence Module																																																										
5	2015	Canyon	Body	Radio																																																										
5	2015	Canyon	Body	Amplifier																																																										
5	2015	Canyon	Body	Human Machine Interface Control Module																																																										
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																																										
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
5	2015	Canyon	Body	Parking Assist Control Module																																																										
5	2015	Canyon	Body	Frontview Camera Module																																																										
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
5	2016	Canyon	Powertrain	Transfer Case Control Module																																																										
5	2016	Canyon	Chassis	Electronic Brake Control Module																																																										
5	2016	Canyon	Chassis	Power Steering Control Module																																																										
5	2016	Canyon	Body	Body Control Module																																																										
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
5	2016	Canyon	Body	Passenger Presence Module																																																										
5	2016	Canyon	Body	Trailer Interface Control Module																																																										
5	2016	Canyon	Body	Radio																																																										
5	2016	Canyon	Body	Amplifier																																																										
5	2016	Canyon	Body	Human Machine Interface Control Module																																																										
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																																										
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
5	2016	Canyon	Body	Frontview Camera Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
6	2011	ALL	Chassis	Electronic Brake Control Module																																																										
6	2011	ALL	Body	Body Control Module																																																										
6	2011	ALL	Body	Digital Radio Receiver																																																										
6	2011	ALL	Body	Generator Battery Control Module																																																										
6	2011	ALL	Body	Instrument Panel Cluster																																																										
6	2011	ALL	Body	Passenger Presence System																																																										
6	2011	ALL	Body	Personal Audio Link Module																																																										
6	2011	ALL	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
6	2011	ALL	Body	Uplevel Radio																																																										
6	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
6	2011	ALL	Body	Theft Deterrent Module																																																										
6	2011	ALL	Body	Vehicle Comm. Interface Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
6	2012	ALL	Chassis	Electronic Brake Control Module																																																										
6	2012	ALL	Body	Body Control Module																																																										
6	2012	ALL	Body	Digital Radio Receiver																																																										
6	2012	ALL	Body	Generator Battery Control Module																																																										
6	2012	ALL	Body	Instrument Panel Cluster																																																										
6	2012	ALL	Body	Passenger Presence System																																																										
6	2012	ALL	Body	Personal Audio Link Module																																																										
6	2012	ALL	Body	Base Radio																																																										
6	2012	ALL	Body	Uplevel Radio																																																										
6	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
6	2012	ALL	Body	Theft Deterrent Module																																																										
6	2012	ALL	Body	Vehicle Comm. Interface Module																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
6	2015	Canyon	Powertrain	Chassis Control Module																																																										
6	2015	Canyon	Powertrain	Transfer Case Control Module																																																										
6	2015	Canyon	Chassis	Electronic Brake Control Module																																																										
6	2015	Canyon	Chassis	Power Steering Control Module																																																										
6	2015	Canyon	Body	Body Control Module																																																										
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
6	2015	Canyon	Body	Passenger Presence Module																																																										
6	2015	Canyon	Body	Radio																																																										
6	2015	Canyon	Body	Amplifier																																																										
6	2015	Canyon	Body	Human Machine Interface Control Module																																																										
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																																										
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
6	2015	Canyon	Body	Parking Assist Control Module																																																										
6	2015	Canyon	Body	Frontview Camera Module																																																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
6	2016	Canyon	Powertrain	Transfer Case Control Module																																																										
6	2016	Canyon	Chassis	Electronic Brake Control Module																																																										
6	2016	Canyon	Chassis	Power Steering Control Module																																																										
6	2016	Canyon	Body	Body Control Module																																																										
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
6	2016	Canyon	Body	Passenger Presence Module																																																										
6	2016	Canyon	Body	Trailer Interface Control Module																																																										
6	2016	Canyon	Body	Radio																																																										
6	2016	Canyon	Body	Amplifier																																																										
6	2016	Canyon	Body	Human Machine Interface Control Module																																																										
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																																										
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
6	2016	Canyon	Body	Frontview Camera Module																																																										
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																				
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2011	Express/Savana	Body	Body Control Module																																																										
7	2011	Express/Savana	Body	Digital Radio Receiver																																																										
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																										
7	2011	Express/Savana	Body	Passenger Presence System																																																										
7	2011	Express/Savana	Body	Radio																																																										
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
7	2011	Express/Savana	Body	Rollover Sensor																																																										
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
7	2011	Express/Savana	Body	Theft Deterrent Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																						
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2011	Express Access/Savana Pro	Body	Body Control Module																																																												
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																												
7	2011	Express Access/Savana Pro	Body	Radio																																																												
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																												
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																							
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2012	Express/Savana	Body	Body Control Module																																																												
7	2012	Express/Savana	Body	Digital Radio Receiver																																																												
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																												
7	2012	Express/Savana	Body	Passenger Presence System																																																												
7	2012	Express/Savana	Body	Radio																																																												
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
7	2012	Express/Savana	Body	Rollover Sensor																																																												
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
7	2012	Express/Savana	Body	Theft Deterrent Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																						
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2012	Express Access/Savana Pro	Body	Body Control Module																																																													
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																													
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																													
7	2012	Express Access/Savana Pro	Body	Radio																																																													
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																													
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																													
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																													
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																													
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																													
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																													
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																													
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
7	2013	Express/Savana	Body	Body Control Module																																																													
7	2013	Express/Savana	Body	Digital Radio Receiver																																																													
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																													
7	2013	Express/Savana	Body	Passenger Presence System																																																													
7	2013	Express/Savana	Body	Radio																																																													
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
7	2013	Express/Savana	Body	Rollover Sensor																																																													
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
7	2013	Express/Savana	Body	Theft Deterrent Module																																																													
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module	V	V	V	V	V																																																						
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2013	Express Access/Savana Pro	Body	Body Control Module																																																												
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																												
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																												
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																												
7	2013	Express Access/Savana Pro	Body	Radio																																																												
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																												
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																												
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V																																																	
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
7	2014	Savana	Chassis	Electronic Brake Control Module																																																												
7	2014	Savana	Body	Body Control Module																																																												
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
7	2014	Savana	Body	Passenger Presence Module																																																												
7	2014	Savana	Body	Rollover Sensor Module																																																												
7	2014	Savana	Body	Instrument Cluster																																																												
7	2014	Savana	Body	Chime Alarm Control Module																																																												
7	2014	Savana	Body	Base Radio																																																												
7	2014	Savana	Body	Navigation Radio																																																												
7	2014	Savana	Body	Uplevel Radio																																																												
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																												
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																												
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
7	2014	Savana	Body	Auxiliary Heater Control Module																																																										
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2014	Savana	Body	Parking Assist Control Module																																																										
7	2014	Savana	Body	Theft Deterrent Module																																																										
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																															
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2015	Savana	Chassis	Electronic Brake Control Module																																																										
7	2015	Savana	Body	Body Control Module																																																										
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2015	Savana	Body	Rollover Sensor Module																																																										
7	2015	Savana	Body	Instrument Cluster																																																										
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
7	2015	Savana	Body	Auxiliary Heater Control Module																																																										
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2015	Savana	Body	Parking Assist Control Module																																																										
7	2015	Savana	Body	Theft Deterrent Module																																																										
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																															
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2016	Savana	Chassis	Electronic Brake Control Module																																																										
7	2016	Savana	Body	Body Control Module																																																										
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2016	Savana	Body	Instrument Cluster																																																										
7	2016	Savana	Body	Chime Alarm Control Module																																																										
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
7	2016	Savana	Body	Auxiliary Heater Control Module																																																										
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2016	Savana	Body	Parking Assist Control Module																																																										
7	2016	Savana	Body	Theft Deterrent Module																																																										
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2011	Express/Savana	Body	Body Control Module																																																									
8	2011	Express/Savana	Body	Digital Radio Receiver																																																									
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																									
8	2011	Express/Savana	Body	Passenger Presence System																																																									
8	2011	Express/Savana	Body	Radio																																																									
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
8	2011	Express/Savana	Body	Rollover Sensor																																																									
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
8	2011	Express/Savana	Body	Theft Deterrent Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2011	Express Access/Savana Pro	Body	Body Control Module																																																									
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																									
8	2011	Express Access/Savana Pro	Body	Radio																																																									
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																									
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2012	Express/Savana	Body	Body Control Module																																																									
8	2012	Express/Savana	Body	Digital Radio Receiver																																																									
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																									
8	2012	Express/Savana	Body	Passenger Presence System																																																									
8	2012	Express/Savana	Body	Radio																																																									
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
8	2012	Express/Savana	Body	Rollover Sensor																																																									
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
8	2012	Express/Savana	Body	Theft Deterrent Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2012	Express Access/Savana Pro	Body	Body Control Module																																																									
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																									
8	2012	Express Access/Savana Pro	Body	Radio																																																									
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																									
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
8	2013	Express/Savana	Body	Body Control Module																																																									
8	2013	Express/Savana	Body	Digital Radio Receiver																																																									
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																									
8	2013	Express/Savana	Body	Navigation Radio																																																									
8	2013	Express/Savana	Body	Park Assist Module																																																									
8	2013	Express/Savana	Body	Passenger Presence System																																																									
8	2013	Express/Savana	Body	Radio																																																									
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
8	2013	Express/Savana	Body	Rollover Sensor																																																									
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
8	2013	Express/Savana	Body	Theft Deterrent Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
8	2013	Express Access/Savana Pro	Body	Body Control Module																																																											
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																											
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																											
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																																											
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																											
8	2013	Express Access/Savana Pro	Body	Radio																																																											
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																											
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																											
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																											
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																											
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																											
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																											
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																											
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																											
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
8	2014	Savana	Chassis	Electronic Brake Control Module																																																											
8	2014	Savana	Body	Body Control Module																																																											
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
8	2014	Savana	Body	Passenger Presence Module																																																											
8	2014	Savana	Body	Rollover Sensor Module																																																											
8	2014	Savana	Body	Instrument Cluster																																																											
8	2014	Savana	Body	Chime Alarm Control Module																																																											
8	2014	Savana	Body	Base Radio																																																											
8	2014	Savana	Body	Navigation Radio																																																											
8	2014	Savana	Body	Uplevel Radio																																																											
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																											
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											
8	2014	Savana	Body	Auxiliary Heater Control Module																																																											
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																											
8	2014	Savana	Body	Parking Assist Control Module																																																											
8	2014	Savana	Body	Theft Deterrent Module																																																											
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																											
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																											
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																													
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																		
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																													
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
8	2015	Savana	Chassis	Electronic Brake Control Module																																																													
8	2015	Savana	Body	Body Control Module																																																												
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
8	2015	Savana	Body	Rollover Sensor Module																																																												
8	2015	Savana	Body	Instrument Cluster																																																												
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																												
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																												
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																												
8	2015	Savana	Body	Auxiliary Heater Control Module																																																												
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																												
8	2015	Savana	Body	Parking Assist Control Module																																																												
8	2015	Savana	Body	Theft Deterrent Module																																																												
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module	V	V	V	V	V	V	V	V	V	V	V																																																		
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																													
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
8	2016	Savana	Chassis	Electronic Brake Control Module																																																													
8	2016	Savana	Body	Body Control Module																																																												
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
8	2016	Savana	Body	Instrument Cluster																																																												
8	2016	Savana	Body	Chime Alarm Control Module																																																												
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																												
8	2016	Savana	Body	Telematics Communication Interface Control Module																																																												
8	2016	Savana	Body	Auxiliary Heater Control Module																																																												
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																												
8	2016	Savana	Body	Parking Assist Control Module																																																												
8	2016	Savana	Body	Theft Deterrent Module																																																												
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																												
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																												
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																												
ALL	2004	ALL	Chassis	ABS																																																												
ALL	2004	ALL	Chassis	Air Suspension																																																												
ALL	2004	ALL	Body	Amplifier (Bose)																																																												
ALL	2004	ALL	Body	Body Control Module																																																												
ALL	2004	ALL	Body	Digital Radio Receiver																																																												
ALL	2004	ALL	Body	Driver Door Module																																																												
ALL	2004	ALL	Body	Driver Seat Module																																																												
ALL	2004	ALL	Body	Heating and Air Conditioning																																																												
ALL	2004	ALL	Body	Instrument Panel Cluster																																																												
ALL	2004	ALL	Body	OnStar																																																											
ALL	2004	ALL	Body	Passenger Door Module																																																												

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
ALL	2004	ALL	Body	Uplevel Radio																																																									
ALL	2004	ALL	Body	Navigation Radio																																																									
ALL	2004	ALL	Body	Rear Seat Audio																																																									
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																									
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									
ALL	2005	ALL	Chassis	ABS																																																									
ALL	2005	ALL	Chassis	Air Suspension																																																									
ALL	2005	ALL	Body	Body Control Module																																																									
ALL	2005	ALL	Body	Digital Radio Receiver																																																									
ALL	2005	ALL	Body	Driver Door Module (SUV)																																																									
ALL	2005	ALL	Body	Driver Door Module (SUT)																																																									
ALL	2005	ALL	Body	Driver Seat Module																																																									
ALL	2005	ALL	Body	Heating and Air Conditioning																																																									
ALL	2005	ALL	Body	Instrument Panel Cluster																																																									
ALL	2005	ALL	Body	Passenger Door Module																																																									
ALL	2005	ALL	Body	Uplevel Radio																																																									
ALL	2005	ALL	Body	Navigation Radio																																																									
ALL	2005	ALL	Body	Rear Seat Audio																																																									
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																									
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									
ALL	2006	H2	Chassis	ABS																																																									
ALL	2006	H2	Chassis	Air Suspension																																																									
ALL	2006	H2	Body	Body Control Module																																																									
ALL	2006	H2	Body	Digital Radio Receiver																																																									
ALL	2006	H2	Body	Driver Door Module (SUV)																																																									
ALL	2006	H2	Body	Driver Door Module (SUT)																																																									
ALL	2006	H2	Body	Driver Seat Module																																																									
ALL	2006	H2	Body	Heating and Air Conditioning																																																									
ALL	2006	H2	Body	Instrument Panel Cluster																																																									
ALL	2006	H2	Body	Passenger Door Module																																																									
ALL	2006	H2	Body	Uplevel Radio																																																									
ALL	2006	H2	Body	Navigation Radio																																																									
ALL	2006	H2	Body	Rear Seat Audio																																																									
ALL	2006	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2006	H3	Powertrain	Engine Control Module																																																									
ALL	2006	H3	Powertrain	Transmission Control Module																																																									
ALL	2006	H3	Powertrain	Transfer Case Control Module																																																									
ALL	2006	H3	Chassis	Antilock Brake System																																																									
ALL	2006	H3	Body	Body Control Module																																																									
ALL	2006	H3	Body	Digital Radio Receiver																																																									
ALL	2006	H3	Body	Instrument Panel Cluster																																																									
ALL	2006	H3	Body	Uplevel Radio																																																									
ALL	2006	H3	Body	Navigation Radio																																																									
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																																									
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																									
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
ALL	2007	H2	Chassis	ABS																																																									
ALL	2007	H2	Chassis	Air Suspension																																																									
ALL	2007	H2	Body	Amplifier (Bose)																																																									
ALL	2007	H2	Body	Body Control Module																																																									
ALL	2007	H2	Body	Digital Radio Receiver																																																									
ALL	2007	H2	Body	Driver Door Module (SUV)																																																									
ALL	2007	H2	Body	Driver Door Module (SUT)																																																									
ALL	2007	H2	Body	Driver Seat Module																																																									
ALL	2007	H2	Body	HVAC Control Module																																																									
ALL	2007	H2	Body	Instrument Panel Cluster																																																									
ALL	2007	H2	Body	Passenger Door Module																																																									
ALL	2007	H2	Body	Uplevel Radio																																																									
ALL	2007	H2	Body	Navigation Radio																																																									
ALL	2007	H2	Body	Rear Seat Audio																																																								V		
ALL	2007	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																																									
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																									
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																									
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																									
ALL	2007	H3	Chassis	EBCM																																																									
ALL	2007	H3	Body	Body Control Module (5GT)																																																									
ALL	2007	H3	Body	Body Control Module (ADM)																																																									
ALL	2007	H3	Body	Digital Radio Receiver																																																									
ALL	2007	H3	Body	Generator Battery Control Module																																																									
ALL	2007	H3	Body	Instrument Panel Cluster																																																									
ALL	2007	H3	Body	Personal Audio Link Module																																																									
ALL	2007	H3	Body	Uplevel Radio																																																									
ALL	2007	H3	Body	Navigation Radio																																																									
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																																									
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																									
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																									
ALL	2008	H2	Chassis	Air SCM																																																									
ALL	2008	H2	Chassis	EBCM																																																									
ALL	2008	H2	Body	Amplifier (Bose)																																																									
ALL	2008	H2	Body	Body Control Module																																																									
ALL	2008	H2	Body	Digital Radio Receiver																																																									
ALL	2008	H2	Body	Driver Door Switch																																																									
ALL	2008	H2	Body	HVAC Control Module																																																									
ALL	2008	H2	Body	Instrument Panel Cluster																																																									
ALL	2008	H2	Body	Memory Seat Module																																																									
ALL	2008	H2	Body	Passenger Door Switch																																																									
ALL	2008	H2	Body	Radio																																																									
ALL	2008	H2	Body	Rear Heated Seat Module																																																									
ALL	2008	H2	Body	Rear HVAC/RSA																																																									
ALL	2008	H2	Body	Rollover Sensor																																																									
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2008	H2	Body	Theft Deterrent Module																																																									
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																																									

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																																										
ALL	2008	H3	Chassis	EBCM																																																										
ALL	2008	H3	Body	Body Control Module (5GT)																																																										
ALL	2008	H3	Body	Body Control Module (ADM)																																																										
ALL	2008	H3	Body	Digital Radio Receiver																																																										
ALL	2008	H3	Body	Generator Battery Control Module																																																										
ALL	2008	H3	Body	Instrument Panel Cluster																																																										
ALL	2008	H3	Body	Personal Audio Link Module																																																										
ALL	2008	H3	Body	Uplevel Radio																																																										
ALL	2008	H3	Body	Navigation Radio																																																										
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	H3	Body	Theft Deterrent Module																																																										
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2009	H2	Chassis	Air SCM																																																										
ALL	2009	H2	Chassis	EBCM																																																										
ALL	2009	H2	Body	Amplifier (Bose)																																																										
ALL	2009	H2	Body	Body Control Module																																																										
ALL	2009	H2	Body	Digital Radio Receiver																																																										
ALL	2009	H2	Body	Driver Door Switch																																																										
ALL	2009	H2	Body	HVAC Control Module																																																										
ALL	2009	H2	Body	Instrument Panel Cluster																																																										
ALL	2009	H2	Body	Memory Seat Module																																																										
ALL	2009	H2	Body	Passenger Door Switch																																																										
ALL	2009	H2	Body	Radio																																																										
ALL	2009	H2	Body	Rear Heated Seat Module																																																										
ALL	2009	H2	Body	Rear HVAC/RSA																																																										
ALL	2009	H2	Body	Rollover Sensor																																																										
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	H2	Body	Theft Deterrent Module																																																										
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																																											
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																																											
ALL	2009	H3	Chassis	EBCM																																																											
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																																											
ALL	2009	H3	Body	Body Control Module (ADM)																																																											
ALL	2009	H3	Body	Digital Radio Receiver																																																											
ALL	2009	H3	Body	Generator Battery Control Module																																																											
ALL	2009	H3	Body	Instrument Panel Cluster																																																											
ALL	2009	H3	Body	Personal Audio Link Module																																																											
ALL	2009	H3	Body	Uplevel Radio																																																											
ALL	2009	H3	Body	Navigation Radio																																																											
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																																											
ALL	2009	H3	Body	Theft Deterrent Module																																																											
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																																											
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																											
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																											
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																											
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																											
ALL	2010	H2	Chassis	Air SCM																																																											
ALL	2010	H2	Chassis	EBCM																																																											
ALL	2010	H2	Body	Amplifier (Bose)																																																											
ALL	2010	H2	Body	Body Control Module																																																											
ALL	2010	H2	Body	Digital Radio Receiver																																																											
ALL	2010	H2	Body	Driver Door Switch																																																											
ALL	2010	H2	Body	HVAC Control Module																																																											
ALL	2010	H2	Body	Instrument Panel Cluster																																																											
ALL	2010	H2	Body	Memory Seat Module																																																											
ALL	2010	H2	Body	Passenger Door Switch																																																											
ALL	2010	H2	Body	Personal Audio Link Module																																																											
ALL	2010	H2	Body	Radio																																																											
ALL	2010	H2	Body	Rear Heated Seat Module																																																											
ALL	2010	H2	Body	Rear HVAC/RSA																																																											
ALL	2010	H2	Body	Rollover Sensor																																																											
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																																											
ALL	2010	H2	Body	Theft Deterrent Module																																																											
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																																											
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																											
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																											
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																											
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																											
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																											
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module																																																											
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																											
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																																											
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																																											
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																																											
ALL	2010	H3	Chassis	EBCM																																																											
ALL	2010	H3	Body	Body Control Module																																																											
ALL	2010	H3	Body	Digital Radio Receiver																																																											
ALL	2010	H3	Body	Generator Battery Control Module																																																											
ALL	2010	H3	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	NOx Sensor 2 Reset	Reductant Fluid Tank Level Reset	Reductant Injector Reset	Reductant System Data Reset	Reductant System Reset	Cylinder 1 Fuel Injector Correction Value Reset	Cylinder 2 Fuel Injector Correction Value Reset	Cylinder 3 Fuel Injector Correction Value Reset	Cylinder 4 Fuel Injector Correction Value Reset	All Cylinders Fuel Injector Correction Value Reset	Fuel Injector Correction Value Preset	1.Engine Data 1	2.Engine Data 2	3.Engine Data 3	4.HO2S Data	TIM Data	1.SIR Data	2.Module Information	Central Locking	ID Information	Learn IMT Valve Adapts.	TAC System	Engine	CO Adjust (leaded fuel only)	Reset EGR Adapts.	Reset Fuel Trim	Service cleaning procedure	Fast learn adapt. process	Cooling HVAC Data	CruisePTOTractionData	Cyl Deactivation Data	Electrical Theft Data	Steering Position Sensor Centering	Input Data 1	Input Data 2	Trip Information	Hourmeter	Substitution Detection 1	Substitution Detection 2	SPI Data	Output Driver Data	Ambient Air Temperature Instant Update	Transmission Shift Data	Transmission Solenoid Valve Data	Transmission Adaptive Torque Reset	High Voltage Disable Data	1. Engine Data 1	2. Engine Data 2	3. Engine Data 3	4. Fuel Trim Data	5. Misfire Data	Line PC Solenoid Data	Input	Trap Alert System	Tire Pressure Reset	Point of Sale
ALL	2010	H3	Body	Personal Audio Link Module																																																												
ALL	2010	H3	Body	Uplevel Radio																																																													
ALL	2010	H3	Body	Navigation Radio																																																													
ALL	2010	H3	Body	Supplemental Inflatable Restraint																																																													
ALL	2010	H3	Body	Theft Deterrent Module																																																													
ALL	2010	H3	Body	Vehicle Comm. Interface Module																																																													

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																				V																																						
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																						
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																				V																																						
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																						
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																						
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																				V																																						
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																						
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																										
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2004	ALL	Chassis	ESC																																																									
C	2004	ALL	Chassis	Rear Wheel Steering																																																										
C	2004	ALL	Chassis	Tire Pressure Monitor																																																										
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2004	ALL	Chassis	VSES																																																									
C	2004	ALL	Body	Amplifier (Bose)																							V																																		
C	2004	ALL	Body	Body Control Module																																																									
C	2004	ALL	Body	CD Changer																																																									
C	2004	ALL	Body	Chime																																																									
C	2004	ALL	Body	Driver Door Module																																																									
C	2004	ALL	Body	Driver Seat Module																								V																										V							
C	2004	ALL	Body	Heating and Air Conditioning Auto																								V																											V	V					
C	2004	ALL	Body	Heating and Air Conditioning Manual																								V																											V	V					
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																								V																											V	V					
C	2004	ALL	Body	Instrument Panel Cluster																V	V							V																																	
C	2004	ALL	Body	OnStar																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2004	ALL	Body	Passenger Door Module																																																					V	V		
C	2004	ALL	Body	Passenger Presence System																																																						V		
C	2004	ALL	Body	Radio Base																																																								
C	2004	ALL	Body	Radio Uplevel																																																								
C	2004	ALL	Body	Radio Navigation																																																								
C	2004	ALL	Body	Rear Aux. Climate Module																							V																											V					V
C	2004	ALL	Body	Rear HVAC																																																								
C	2004	ALL	Body	Rear Seat Audio																																																								
C	2004	ALL	Body	Rear Seat Entertainment																																																								
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2004	ALL	Body	Vehicle Theft Deterrent																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																				V																																				
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																				V																																				
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																				V																																				
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																				
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																				V																																				
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																				
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																								
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																								
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																								
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																								
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																								
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
C	2005	ALL	Chassis	ESC																																																								
C	2005	ALL	Chassis	Rear Wheel Steering																																																								
C	2005	ALL	Chassis	Tire Pressure Monitor																																																								
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																								
C	2005	ALL	Chassis	VSES																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2005	ALL	Body	Amplifier (Bose)																							V																																			
C	2005	ALL	Body	Body Control Module																																																										
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																																										
C	2005	ALL	Body	Driver Seat Module																								V																										V								
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																								V																											V	V						
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																								V																											V	V						
C	2005	ALL	Body	Heating and Air Conditioning Manual																								V																											V	V						
C	2005	ALL	Body	Instrument Panel Cluster																V	V							V																																		
C	2005	ALL	Body	Passenger Door Module																																																						V	V		
C	2005	ALL	Body	Passenger Presence System																																																							V		
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio																																																										
C	2005	ALL	Body	Rear Aux. Climate Module																								V																											V							V
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2005	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																				V																																						
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																						
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																				V																																						
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																				V																																						
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																						
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																						
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																				V																																						
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																						
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																										
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																										
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																										
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
C	2006	ALL	Chassis	ESC																																																									
C	2006	ALL	Chassis	Tire Pressure Monitor																																																V									
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
C	2006	ALL	Chassis	VSES																																																									
C	2006	ALL	Body	Amplifier (Bose)																							V																																			
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																									
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																								V																									V									
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																								V																										V	V						
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																								V																										V	V						
C	2006	ALL	Body	Heating and Air Conditioning Manual																								V																										V	V						
C	2006	ALL	Body	Instrument Panel Cluster																V	V							V																																	
C	2006	ALL	Body	Passenger Door Module																																																				V	V		
C	2006	ALL	Body	Passenger Presence System																																																					V		
C	2006	ALL	Body	Base Radio																																																								
C	2006	ALL	Body	Uplevel Radio																																																								
C	2006	ALL	Body	Navigation Radio																																																								
C	2006	ALL	Body	Rear Aux. Climate Module																								V																										V						V
C	2006	ALL	Body	Rear HVAC																																																								
C	2006	ALL	Body	Rear Seat Audio																																																								
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
C	2006	ALL	Body	Vehicle Theft Deterrent																																																								
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																								
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module											V																																													
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																		
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module					V						V																																													
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																		
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V	V																																													
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																									
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																		
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																													
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																													
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																																
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																						
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																																	
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module											V																																																	
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V	V																																																	
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																						
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																																	
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																						
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Sierra	Chassis	Electronic Suspension Control																																																												
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2007	Sierra	Body	Amplifier (Bose)																																																												
C	2007	Sierra	Body	Body Control Module																																																												
C	2007	Sierra	Body	Body Control Module (aux.)																																																												
C	2007	Sierra	Body	Digital Radio Receiver																																																												
C	2007	Sierra	Body	Driver Door Switch																																																												
C	2007	Sierra	Body	HVAC Control Module Auto									V																																																			
C	2007	Sierra	Body	HVAC Control Module Manual																																																												
C	2007	Sierra	Body	Instrument Panel Cluster																																																												
C	2007	Sierra	Body	Memory Seat Module																																																												
C	2007	Sierra	Body	Park Assist Module																																																												
C	2007	Sierra	Body	Passenger Door Switch																																																												
C	2007	Sierra	Body	Passenger Presence System																																																												
C	2007	Sierra	Body	Radio																																																											
C	2007	Sierra	Body	Rear Heated Seat Module																																																												
C	2007	Sierra	Body	Rear HVAC/RSA																																																												
C	2007	Sierra	Body	Rollover Sensor																																																												
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2007	Sierra	Body	Theft Deterrent Module																																																												
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																																		
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																						
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																																	
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																						
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																																	
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																						
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																																		
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																													
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Yukon	Chassis	Electronic Suspension Control																																																												
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																												
C	2007	Yukon	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2007	Yukon	Body	Assist Step Controller																																																											
C	2007	Yukon	Body	Body Control Module																																																											
C	2007	Yukon	Body	Body Control Module (aux.)																																																											
C	2007	Yukon	Body	Digital Radio Receiver																																																											
C	2007	Yukon	Body	Driver Door Switch																																																											
C	2007	Yukon	Body	HVAC Control Module Auto									V																																																		
C	2007	Yukon	Body	HVAC Control Module Manual																																																												
C	2007	Yukon	Body	Instrument Panel Cluster																																																												
C	2007	Yukon	Body	Lift Gate Module																																																												
C	2007	Yukon	Body	Memory Seat Module																																																												
C	2007	Yukon	Body	Park Assist Module																																																												
C	2007	Yukon	Body	Passenger Door Switch																																																												
C	2007	Yukon	Body	Passenger Presence System																																																												
C	2007	Yukon	Body	Radio																																																												
C	2007	Yukon	Body	Rear Heated Seat Module																																																												
C	2007	Yukon	Body	Rear HVAC/RSA																																																												
C	2007	Yukon	Body	Rollover Sensor																																																												
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																																												
C	2007	Yukon	Body	Theft Deterrent Module																																																												
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module					V						V																																																	
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																						
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																																	
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																																	
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																						
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																																	
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V	V																																																	
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																						
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																																	
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																						
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																												
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																												
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2007	Yukon XL	Body	Amplifier (Bose)																																																												
C	2007	Yukon XL	Body	Assist Step Controller																																																												
C	2007	Yukon XL	Body	Body Control Module																																																												
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2007	Yukon XL	Body	Digital Radio Receiver																																																												
C	2007	Yukon XL	Body	Driver Door Switch																																																												
C	2007	Yukon XL	Body	HVAC Control Module Auto									V																																																		
C	2007	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2007	Yukon XL	Body	Lift Gate Module																																																												
C	2007	Yukon XL	Body	Memory Seat Module																																																												
C	2007	Yukon XL	Body	Park Assist Module																																																												
C	2007	Yukon XL	Body	Passenger Door Switch																																																												
C	2007	Yukon XL	Body	Passenger Presence System																																																												
C	2007	Yukon XL	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2007	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2007	Yukon XL	Body	Rollover Sensor																																																										
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
C	2007	Yukon XL	Body	Theft Deterrent Module																																																										
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																				
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																				
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V	V																																															
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																				
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																															
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																				
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																																
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																				
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																																
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module											V																																																
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																				
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																	
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																				
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																											
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																											
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2008	Sierra	Chassis	Electronic Suspension Control																																																											
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																											
C	2008	Sierra	Body	Amplifier (Bose)																																																											
C	2008	Sierra	Body	Body Control Module																																																										
C	2008	Sierra	Body	Body Control Module (aux.)																																																											
C	2008	Sierra	Body	Digital Radio Receiver																																																											
C	2008	Sierra	Body	Driver Door Switch																																																											
C	2008	Sierra	Body	HVAC Control Module Auto									V																																																		
C	2008	Sierra	Body	HVAC Control Module Manual																																																											
C	2008	Sierra	Body	Instrument Panel Cluster																																																											
C	2008	Sierra	Body	Memory Seat Module																																																											
C	2008	Sierra	Body	Park Assist Module																																																											
C	2008	Sierra	Body	Passenger Door Switch																																																											
C	2008	Sierra	Body	Passenger Presence System																																																											
C	2008	Sierra	Body	Radio																																																											
C	2008	Sierra	Body	Rear Heated Seat Module																																																											
C	2008	Sierra	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2008	Sierra	Body	Rollover Sensor																																																								
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																																								
C	2008	Sierra	Body	Theft Deterrent Module																																																								
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																														
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																		
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																													
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																		
C	2008	Yukon	Chassis	Electronic Brake Control Module																																																								
C	2008	Yukon	Chassis	Electronic Suspension Control																																																								
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																								
C	2008	Yukon	Body	Amplifier (Bose)																																																								
C	2008	Yukon	Body	Assist Step Controller																																																								
C	2008	Yukon	Body	Body Control Module																																																								
C	2008	Yukon	Body	Body Control Module (aux.)																																																								
C	2008	Yukon	Body	Digital Radio Receiver																																																								
C	2008	Yukon	Body	Driver Door Switch																																																								
C	2008	Yukon	Body	HVAC Control Module Auto									V																																															
C	2008	Yukon	Body	HVAC Control Module Manual																																																								
C	2008	Yukon	Body	Instrument Panel Cluster																																																								
C	2008	Yukon	Body	Lift Gate Module																																																								
C	2008	Yukon	Body	Memory Seat Module																																																								
C	2008	Yukon	Body	Park Assist Module																																																								
C	2008	Yukon	Body	Passenger Door Switch																																																								
C	2008	Yukon	Body	Passenger Presence System																																																								
C	2008	Yukon	Body	Radio																																																								
C	2008	Yukon	Body	Rear Heated Seat Module																																																								
C	2008	Yukon	Body	Rear HVAC/RSA																																																								
C	2008	Yukon	Body	Rollover Sensor																																																								
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																																								
C	2008	Yukon	Body	Theft Deterrent Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																								
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																										
C	2008	Yukon Hybrid	Body	Body Control Module																																																										
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																										
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																										
C	2008	Yukon Hybrid	Body	HVAC Control Module									V																																																	
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
C	2008	Yukon Hybrid	Body	Lift Gate Module																																																										
C	2008	Yukon Hybrid	Body	Memory Seat Module																																																										
C	2008	Yukon Hybrid	Body	Park Assist Module																																																										
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																										
C	2008	Yukon Hybrid	Body	Passenger Presence System																																																										
C	2008	Yukon Hybrid	Body	Radio																																																										
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																										
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																										
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																			
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																															
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																			
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																															
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																			
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																			
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon XL	Body	Amplifier (Bose)																																																										
C	2008	Yukon XL	Body	Assist Step Controller																																																										
C	2008	Yukon XL	Body	Body Control Module																																																										
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2008	Yukon XL	Body	Digital Radio Receiver																																																										
C	2008	Yukon XL	Body	Driver Door Switch																																																										
C	2008	Yukon XL	Body	HVAC Control Module Auto									V																																																
C	2008	Yukon XL	Body	HVAC Control Module Manual																																																										
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2008	Yukon XL	Body	Lift Gate Module																																																										
C	2008	Yukon XL	Body	Memory Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2008	Yukon XL	Body	Park Assist Module																																																								
C	2008	Yukon XL	Body	Passenger Door Switch																																																								
C	2008	Yukon XL	Body	Passenger Presence System																																																								
C	2008	Yukon XL	Body	Radio																																																								
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																								
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																								
C	2008	Yukon XL	Body	Rollover Sensor																																																								
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
C	2008	Yukon XL	Body	Theft Deterrent Module																																																								
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																														
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																													
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																								
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																													
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																													
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual										V																																													
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																								
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																								
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
C	2009	Sierra	Chassis	Electronic Suspension Control																																																								
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																								
C	2009	Sierra	Body	Amplifier (Bose)																																																								
C	2009	Sierra	Body	Body Control Module																																																								
C	2009	Sierra	Body	Body Control Module (aux.)																																																								
C	2009	Sierra	Body	Digital Radio Receiver																																																								
C	2009	Sierra	Body	Driver Door Switch																																																								
C	2009	Sierra	Body	HVAC Control Module Auto										V																																														

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2009	Sierra	Body	HVAC Control Module Manual																																																								
C	2009	Sierra	Body	Instrument Panel Cluster																																																								
C	2009	Sierra	Body	Memory Seat Module																																																								
C	2009	Sierra	Body	Park Assist Module																																																								
C	2009	Sierra	Body	Passenger Door Switch																																																								
C	2009	Sierra	Body	Passenger Presence System																																																								
C	2009	Sierra	Body	Radio																																																								
C	2009	Sierra	Body	Rear Heated Seat Module																																																								
C	2009	Sierra	Body	Rear HVAC/RSA																																																								
C	2009	Sierra	Body	Rollover Sensor																																																								
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																																								
C	2009	Sierra	Body	Theft Deterrent Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																								
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																								
C	2009	Sierra Hybrid	Body	Body Control Module																																																								
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																								
C	2009	Sierra Hybrid	Body	Driver Door Switch																																																								
C	2009	Sierra Hybrid	Body	HVAC Control Module									V																																															
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
C	2009	Sierra Hybrid	Body	Memory Seat Module																																																								
C	2009	Sierra Hybrid	Body	Park Assist Module																																																								
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																																								
C	2009	Sierra Hybrid	Body	Passenger Presence System																																																								
C	2009	Sierra Hybrid	Body	Radio																																																								
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																								
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed										V																																														
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed										V																																														
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																								
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed										V																																															
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed										V																																															
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
C	2009	Yukon	Chassis	Electronic Brake Control Module																																																										
C	2009	Yukon	Chassis	Electronic Suspension Control																																																										
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																										
C	2009	Yukon	Body	Amplifier (Bose)																																																										
C	2009	Yukon	Body	Assist Step Controller																																																										
C	2009	Yukon	Body	Body Control Module																																																										
C	2009	Yukon	Body	Body Control Module (aux.)																																																										
C	2009	Yukon	Body	Digital Radio Receiver																																																										
C	2009	Yukon	Body	Driver Door Switch																																																										
C	2009	Yukon	Body	HVAC Control Module Auto									V																																																
C	2009	Yukon	Body	HVAC Control Module Manual																																																										
C	2009	Yukon	Body	Instrument Panel Cluster																																																										
C	2009	Yukon	Body	Left Side Object Detection Module																																																										
C	2009	Yukon	Body	Lift Gate Module																																																										
C	2009	Yukon	Body	Memory Seat Module																																																										
C	2009	Yukon	Body	Park Assist Module																																																										
C	2009	Yukon	Body	Passenger Door Switch																																																										
C	2009	Yukon	Body	Passenger Presence System																																																										
C	2009	Yukon	Body	Radio																																																										
C	2009	Yukon	Body	Rear Heated Seat Module																																																										
C	2009	Yukon	Body	Rear HVAC/RSA																																																										
C	2009	Yukon	Body	Right Side Object Detection Module																																																										
C	2009	Yukon	Body	Rollover Sensor																																																										
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																																										
C	2009	Yukon	Body	Theft Deterrent Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																					
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																										
C	2009	Yukon Hybrid	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																												
C	2009	Yukon Hybrid	Body	Driver Door Switch																																																												
C	2009	Yukon Hybrid	Body	Heated Seat Module																																																												
C	2009	Yukon Hybrid	Body	HVAC Control Module									V																																																		
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
C	2009	Yukon Hybrid	Body	Park Assist Module																																																												
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																																												
C	2009	Yukon Hybrid	Body	Passenger Presence System																																																												
C	2009	Yukon Hybrid	Body	Radio																																																												
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																												
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																												
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																		
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																	
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																	
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																	
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2009	Yukon XL	Body	Amplifier (Bose)																																																												
C	2009	Yukon XL	Body	Assist Step Controller																																																												
C	2009	Yukon XL	Body	Body Control Module																																																												
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2009	Yukon XL	Body	Digital Radio Receiver																																																												
C	2009	Yukon XL	Body	Driver Door Switch																																																												
C	2009	Yukon XL	Body	HVAC Control Module Auto									V																																																		
C	2009	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2009	Yukon XL	Body	Left Side Object Detection Module																																																												
C	2009	Yukon XL	Body	Lift Gate Module																																																												
C	2009	Yukon XL	Body	Memory Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2009	Yukon XL	Body	Park Assist Module																																																									
C	2009	Yukon XL	Body	Passenger Door Switch																																																										
C	2009	Yukon XL	Body	Passenger Presence System																																																										
C	2009	Yukon XL	Body	Radio																																																									
C	2009	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2009	Yukon XL	Body	Right Side Object Detection Module																																																										
C	2009	Yukon XL	Body	Rollover Sensor																																																										
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
C	2009	Yukon XL	Body	Theft Deterrent Module																																																										
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																				
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																						V																				
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																						V																				
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2010	Sierra	Chassis	Electronic Suspension Control																																																										
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																										
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra	Body	Amplifier (Bose)																																																										
C	2010	Sierra	Body	Body Control Module																																																										
C	2010	Sierra	Body	Body Control Module (aux.)																																																										
C	2010	Sierra	Body	Digital Radio Receiver																																																										
C	2010	Sierra	Body	Driver Door Switch																																																										
C	2010	Sierra	Body	HVAC Control Module Auto									V																																																
C	2010	Sierra	Body	HVAC Control Module Manual									V																																																
C	2010	Sierra	Body	Instrument Panel Cluster																																																										
C	2010	Sierra	Body	Memory Seat Module																																																										
C	2010	Sierra	Body	Park Assist Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2010	Sierra	Body	Passenger Door Switch																																																								
C	2010	Sierra	Body	Passenger Presence System																																																								
C	2010	Sierra	Body	Radio																																																								
C	2010	Sierra	Body	Rear Heated Seat Module																																																								
C	2010	Sierra	Body	Rear HVAC/RSA																																																								
C	2010	Sierra	Body	Supplemental Inflatable Restraint																																																								
C	2010	Sierra	Body	Theft Deterrent Module																																																								
C	2010	Sierra Hybrid	Powertrain	Engine Control Module					V																																																			
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																								
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																								
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																								
C	2010	Sierra Hybrid	Body	Body Control Module																																																								
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																								
C	2010	Sierra Hybrid	Body	Driver Door Switch																																																								
C	2010	Sierra Hybrid	Body	Heated Seat Module																																																								
C	2010	Sierra Hybrid	Body	HVAC Control Module																																																								
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
C	2010	Sierra Hybrid	Body	Park Assist Module																																																								
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																																								
C	2010	Sierra Hybrid	Body	Passenger Presence System																																																								
C	2010	Sierra Hybrid	Body	Radio																																																								
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																								
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																														
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
C	2010	Yukon	Chassis	Electronic Brake Control Module																																																								
C	2010	Yukon	Chassis	Electronic Suspension Control																																																								
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
C	2010	Yukon	Body	Amplifier (Bose)																																																								
C	2010	Yukon	Body	Assist Step Controller																																																								
C	2010	Yukon	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2010	Yukon	Body	Body Control Module (aux.)																																																									
C	2010	Yukon	Body	Digital Radio Receiver																																																									
C	2010	Yukon	Body	Driver Door Switch																																																									
C	2010	Yukon	Body	HVAC Control Module Auto									V																																																
C	2010	Yukon	Body	HVAC Control Module Manual																																																									
C	2010	Yukon	Body	Instrument Panel Cluster																																																									
C	2010	Yukon	Body	Left Side Object Detection Module																																																									
C	2010	Yukon	Body	Lift Gate Module																																																									
C	2010	Yukon	Body	Memory Seat Module																																																									
C	2010	Yukon	Body	Park Assist Module																																																									
C	2010	Yukon	Body	Passenger Door Switch																																																									
C	2010	Yukon	Body	Passenger Presence System																																																									
C	2010	Yukon	Body	Radio																																																									
C	2010	Yukon	Body	Rear Heated Seat Module																																																									
C	2010	Yukon	Body	Rear HVAC/RSA																																																									
C	2010	Yukon	Body	Right Side Object Detection Module																																																									
C	2010	Yukon	Body	Supplemental Inflatable Restraint																																																									
C	2010	Yukon	Body	Theft Deterrent Module																																																									
C	2010	Yukon Hybrid	Powertrain	Engine Control Module					V																																																				
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																									
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																									
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																									
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																									
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																									
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																									
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																									
C	2010	Yukon Hybrid	Body	Body Control Module																																																									
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																									
C	2010	Yukon Hybrid	Body	Driver Door Switch																																																									
C	2010	Yukon Hybrid	Body	Heated Seat Module																																																									
C	2010	Yukon Hybrid	Body	HVAC Control Module																																																									
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																									
C	2010	Yukon Hybrid	Body	Lift Gate Module																																																									
C	2010	Yukon Hybrid	Body	Park Assist Module																																																									
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																																									
C	2010	Yukon Hybrid	Body	Passenger Presence System																																																									
C	2010	Yukon Hybrid	Body	Radio																																																									
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																									
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																																
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																										
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																										
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2010	Yukon XL	Body	Amplifier (Bose)																																																										
C	2010	Yukon XL	Body	Assist Step Controller																																																										
C	2010	Yukon XL	Body	Body Control Module																																																										
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2010	Yukon XL	Body	Digital Radio Receiver																																																										
C	2010	Yukon XL	Body	Driver Door Switch																																																										
C	2010	Yukon XL	Body	HVAC Control Module Auto									V																																																
C	2010	Yukon XL	Body	HVAC Control Module Manual																																																										
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2010	Yukon XL	Body	Left Side Object Detection Module																																																										
C	2010	Yukon XL	Body	Lift Gate Module																																																										
C	2010	Yukon XL	Body	Memory Seat Module																																																										
C	2010	Yukon XL	Body	Park Assist Module																																																										
C	2010	Yukon XL	Body	Passenger Door Switch																																																										
C	2010	Yukon XL	Body	Passenger Presence System																																																										
C	2010	Yukon XL	Body	Radio																																																										
C	2010	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2010	Yukon XL	Body	Right Side Object Detection Module																																																										
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
C	2010	Yukon XL	Body	Theft Deterrent Module																																																										
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module										V	V																																															
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																										
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2008	ALL	Chassis	Electronic Brake Control Module																																																										
D	2008	ALL	Body	Body Control Module																																																										
D	2008	ALL	Body	Body Control Module (aux.)																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
D	2008	ALL	Body	Headlamp Control Module																																																								
D	2008	ALL	Body	HVAC Control Module Auto																																																								
D	2008	ALL	Body	Instrument Panel Cluster																																																								
D	2008	ALL	Body	Park Assist Module																																																								
D	2008	ALL	Body	Remote Control Door Lock Receiver																																																								
D	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
D	2008	ALL	Body	Theft Deterrent Module																																																								
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module										V	V																																														
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																									
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																									
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																									
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																									
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																									
D	2009	ALL	Chassis	Electronic Brake Control Module																																																									
D	2009	ALL	Body	Body Control Module																																																								
D	2009	ALL	Body	Body Control Module (aux.)																																																								
D	2009	ALL	Body	Headlamp Control Module																																																								
D	2009	ALL	Body	HVAC Control Module Auto																																																								
D	2009	ALL	Body	Instrument Panel Cluster																																																								
D	2009	ALL	Body	Park Assist Module																																																								
D	2009	ALL	Body	Remote Control Door Lock Receiver																																																								
D	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
D	2009	ALL	Body	Theft Deterrent Module																																																								
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module										V	V																																														
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																									
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																									
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																									
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																									
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																									
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																									
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																									
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																									
D	2010	ALL	Chassis	Electronic Brake Control Module																																																									
D	2010	ALL	Body	Body Control Module																																																								
D	2010	ALL	Body	Body Control Module (aux.)																																																								
D	2010	ALL	Body	Headlamp Control Module																																																								
D	2010	ALL	Body	HVAC Control Module Auto																																																								
D	2010	ALL	Body	Instrument Panel Cluster																																																								
D	2010	ALL	Body	Park Assist Module																																																								
D	2010	ALL	Body	Remote Control Door Lock Receiver																																																								
D	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																								
G	2004	Express/Savana	Chassis	VSES																																																								
G	2004	Express/Savana	Body	Body Control Module																																																								
G	2004	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2004	Express/Savana	Body	OnStar																																																								
G	2004	Express/Savana	Body	Base Radio																																																								
G	2004	Express/Savana	Body	Uplevel Radio																																																								
G	2004	Express/Savana	Body	Remote Function Actuation																																																								
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																								
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
G	2004	Express Access/Savana Pro	Chassis	VSES																																																								
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
G	2004	Express Access/Savana Pro	Body	OnStar																																																								
G	2004	Express Access/Savana Pro	Body	Base Radio																																																								
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																								
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																				V																																				
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																				
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																				
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																									
G	2005	Express/Savana	Chassis	VSES																																																									
G	2005	Express/Savana	Body	Body Control Module																																																									
G	2005	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																	
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																									
G	2005	Express/Savana	Body	Base Radio																																																									
G	2005	Express/Savana	Body	Uplevel Radio																																																									
G	2005	Express/Savana	Body	Remote Function Actuation																																																									
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																					
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																									
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																				V																																					
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																					
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																					
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																									
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																									
G	2005	Express Access/Savana Pro	Chassis	VSES																																																									
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																	
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2005	Express Access/Savana Pro	Body	Base Radio																																																									
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																									
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																									
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																					
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																					
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																					
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																									
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																								
G	2006	Express/Savana	Chassis	VSES																																																								
G	2006	Express/Savana	Body	Body Control Module																																																								
G	2006	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2006	Express/Savana	Body	Passenger Presence System																																																								V
G	2006	Express/Savana	Body	Base Radio																																																								
G	2006	Express/Savana	Body	Uplevel Radio																																																								
G	2006	Express/Savana	Body	Remote Function Actuation																																																								
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																								
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																				
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																				
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																								
G	2006	Express Access/Savana Pro	Chassis	VSES																																																								
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																								
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																								
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																								V
G	2006	Express Access/Savana Pro	Body	Base Radio																																																								
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																								
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																								
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																								
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																					
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																				
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																				
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2007	Express/Savana	Body	Body Control Module																																																								
G	2007	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																								
G	2007	Express/Savana	Body	Passenger Presence System																																																						V	
G	2007	Express/Savana	Body	Base Radio																																																							
G	2007	Express/Savana	Body	Uplevel Radio																																																							
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																							
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																							
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																							
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																							
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																				
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																				
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																							
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																				
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																	
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																									V	
G	2007	Express Access/Savana Pro	Body	Radio																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																			
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																															
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module											V																																															
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																				V	V	V																																			
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																															
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module											V																																															
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express/Savana	Body	Body Control Module																																																										
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2008	Express/Savana	Body	Passenger Presence System																																																										
G	2008	Express/Savana	Body	Radio																																																										
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express/Savana	Body	Rollover Sensor																																																										
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2008	Express/Savana	Body	Theft Deterrent Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																															
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module											V																																															
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																				V	V	V																																			
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																															
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module											V																																															
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2008	Express Access/Savana Pro	Body	Radio																																																										
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2009	Express/Savana	Body	Body Control Module																																																										
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2009	Express/Savana	Body	Passenger Presence System																																																										
G	2009	Express/Savana	Body	Radio																																																										
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2009	Express/Savana	Body	Rollover Sensor																																																										
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2009	Express/Savana	Body	Theft Deterrent Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2009	Express Access/Savana Pro	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																								
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																		
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2010	Express/Savana	Body	Body Control Module																																																								
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																								
G	2010	Express/Savana	Body	Passenger Presence System																																																								
G	2010	Express/Savana	Body	Radio																																																								
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
G	2010	Express/Savana	Body	Rollover Sensor																																																								
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
G	2010	Express/Savana	Body	Theft Deterrent Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																		
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2010	Express Access/Savana Pro	Body	Radio																																																											
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																							
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																											
H	2004	Express/Savana	Chassis	VSES																																																											
H	2004	Express/Savana	Body	Body Control Module																																																											
H	2004	Express/Savana	Body	Instrument Panel Cluster																V	V						V																																				
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2004	Express/Savana	Body	OnStar																																																											
H	2004	Express/Savana	Body	Base Radio																																																											
H	2004	Express/Savana	Body	Uplevel Radio																																																											
H	2004	Express/Savana	Body	Remote Function Actuation																																																											
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																							
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																											
H	2004	Express Access/Savana Pro	Chassis	VSES																																																											
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V						V																																				
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
H	2004	Express Access/Savana Pro	Body	OnStar																																																											
H	2004	Express Access/Savana Pro	Body	Base Radio																																																											
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																											
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																							
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																							
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																											
H	2005	Express/Savana	Chassis	VSES																																																											
H	2005	Express/Savana	Body	Body Control Module																																																											
H	2005	Express/Savana	Body	Instrument Panel Cluster																V	V						V																																				
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2005	Express/Savana	Body	Base Radio																																																											
H	2005	Express/Savana	Body	Uplevel Radio																																																											
H	2005	Express/Savana	Body	Remote Function Actuation																																																											
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																							
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																							
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																											
H	2005	Express Access/Savana Pro	Chassis	VSES																																																											

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																			
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
H	2005	Express Access/Savana Pro	Body	Base Radio																																																											
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																											
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																							
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																							
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																											
H	2006	Express/Savana	Chassis	VSES																																																											
H	2006	Express/Savana	Body	Body Control Module																																																											
H	2006	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																				
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2006	Express/Savana	Body	Passenger Presence System																																																									V	
H	2006	Express/Savana	Body	Base Radio																																																											
H	2006	Express/Savana	Body	Uplevel Radio																																																											
H	2006	Express/Savana	Body	Remote Function Actuation																																																											
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																							
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																							
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																											
H	2006	Express Access/Savana Pro	Chassis	VSES																																																											
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																				
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																									V	
H	2006	Express Access/Savana Pro	Body	Base Radio																																																											
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																											
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																							
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																							
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																							
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2007	Express/Savana	Body	Body Control Module																																																											
H	2007	Express/Savana	Body	Instrument Panel Cluster																V	V							V																																				
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2007	Express/Savana	Body	Passenger Presence System																																																									V	
H	2007	Express/Savana	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2007	Express/Savana	Body	Uplevel Radio																																																									
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																									
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																					
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																									
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																				V																																					
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																									
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																				V																																					
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																V	V							V																																	
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																									V
H	2007	Express Access/Savana Pro	Body	Base Radio																																																									
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																									
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																			
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																														
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module											V																																														
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																				V	V	V																																			
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																														
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2008	Express/Savana	Body	Body Control Module																																																									
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2008	Express/Savana	Body	Passenger Presence System																																																									
H	2008	Express/Savana	Body	Radio																																																									
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2008	Express/Savana	Body	Rollover Sensor																																																									
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2008	Express/Savana	Body	Theft Deterrent Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																			
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																														
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module											V																																														
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																				V	V	V																																			
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																														
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2008	Express Access/Savana Pro	Body	Radio																																																									
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2009	Express/Savana	Body	Body Control Module																																																									
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																									
H	2009	Express/Savana	Body	Passenger Presence System																																																									
H	2009	Express/Savana	Body	Radio																																																									
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
H	2009	Express/Savana	Body	Rollover Sensor																																																									
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
H	2009	Express/Savana	Body	Theft Deterrent Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																									
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																									
H	2009	Express Access/Savana Pro	Body	Radio																																																									
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																									
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2010	Express/Savana	Body	Body Control Module																																																								
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																								
H	2010	Express/Savana	Body	Passenger Presence System																																																								
H	2010	Express/Savana	Body	Radio																																																								
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
H	2010	Express/Savana	Body	Rollover Sensor																																																								
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
H	2010	Express/Savana	Body	Theft Deterrent Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																								
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																								
H	2010	Express Access/Savana Pro	Body	Radio																																																								
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																								
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																				V																																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																				V																																				
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																				
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																							
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																							
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																							
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																							
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																				V																																				
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																							
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																							
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																							
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																							
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																							
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																				
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																							
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																							
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																							
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																							
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																							
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																							
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																							
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																							
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																							
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																							
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																							
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																							
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																							
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																							
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																						
K	2004	ALL	Chassis	ESC																																																						
K	2004	ALL	Chassis	Rear Wheel Steering																																																						
K	2004	ALL	Chassis	Tire Pressure Monitor																																														V									
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																						
K	2004	ALL	Chassis	VSES																																																						
K	2004	ALL	Body	Amplifier (Bose)																							V																															
K	2004	ALL	Body	Body Control Module																																																						
K	2004	ALL	Body	CD Changer																																																						
K	2004	ALL	Body	Chime																																																						
K	2004	ALL	Body	Driver Door Module																																																						
K	2004	ALL	Body	Driver Seat Module																								V																								V						
K	2004	ALL	Body	Heating and Air Conditioning Auto																								V																									V	V					
K	2004	ALL	Body	Heating and Air Conditioning Manual																								V																									V	V					
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																								V																									V	V					
K	2004	ALL	Body	Instrument Panel Cluster																V	V							V																															
K	2004	ALL	Body	OnStar																																																						
K	2004	ALL	Body	Passenger Door Module																																																			V	V			
K	2004	ALL	Body	Passenger Presence System																																																					V		
K	2004	ALL	Body	Radio Base																																																						
K	2004	ALL	Body	Radio Uplevel																																																						
K	2004	ALL	Body	Radio Navigation																																																						
K	2004	ALL	Body	Rear Aux. Climate Module																								V																									V					V
K	2004	ALL	Body	Rear HVAC																																																						

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2004	ALL	Body	Rear Seat Audio																																																								
K	2004	ALL	Body	Rear Seat Entertainment																																																								
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2004	ALL	Body	Vehicle Theft Deterrent																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																				V																																				
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																								
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																								
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																								
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																				V																																				
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																								
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																								
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																				V																																				
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																				
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																				
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																				V																																				
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																								
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																								
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																				
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																								
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																								
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																								
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2005	ALL	Chassis	ESC																																																										
K	2005	ALL	Chassis	Rear Wheel Steering																																																										
K	2005	ALL	Chassis	Tire Pressure Monitor																																																										
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2005	ALL	Chassis	VSES																																																										
K	2005	ALL	Body	Amplifier (Bose)																							V																																			
K	2005	ALL	Body	Body Control Module																																																										
K	2005	ALL	Body	CD Changer																																																										
K	2005	ALL	Body	Chime																																																										
K	2005	ALL	Body	Disc Player and Video Display																																																										
K	2005	ALL	Body	Driver Door Module																																																										
K	2005	ALL	Body	Driver Seat Module																								V																										V								
K	2005	ALL	Body	Generator Battery Control Module																																																										
K	2005	ALL	Body	Heating and Air Conditioning Auto																								V																												V	V					
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																								V																												V	V					
K	2005	ALL	Body	Heating and Air Conditioning Manual																								V																												V	V					
K	2005	ALL	Body	Instrument Panel Cluster																V	V							V																																		
K	2005	ALL	Body	Passenger Door Module																																																							V	V		
K	2005	ALL	Body	Passenger Presence System																																																										V
K	2005	ALL	Body	Base Radio																																																										
K	2005	ALL	Body	Uplevel Radio																																																										
K	2005	ALL	Body	Navigation Radio																																																										
K	2005	ALL	Body	Rear Aux. Climate Module																								V																										V							V
K	2005	ALL	Body	Rear HVAC																																																										
K	2005	ALL	Body	Rear Seat Audio																																																										
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																										
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
K	2005	ALL	Body	Vehicle Theft Deterrent																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																				V																																						
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																						
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																				V																																						
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																				V																																						

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																				V																																						
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																				V																																						
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																				V																																						
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																				V																																						
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																									
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																									
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																									
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																									
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																									
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																									
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																									
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																									
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																								
K	2006	ALL	Chassis	ESC																																																								
K	2006	ALL	Chassis	Tire Pressure Monitor																																															V									
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																								
K	2006	ALL	Chassis	VSES																																																								
K	2006	ALL	Body	Amplifier (Bose)																							V																																	
K	2006	ALL	Body	Body Control Module																																																								
K	2006	ALL	Body	CD Changer																																																								
K	2006	ALL	Body	Chime																																																								
K	2006	ALL	Body	Disc Player and Video Display																																																								
K	2006	ALL	Body	Driver Door Module																																																								
K	2006	ALL	Body	Driver Seat Module																								V																								V								
K	2006	ALL	Body	Generator Battery Control Module																																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto																								V																										V	V						

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																								V																											V	V				
K	2006	ALL	Body	Heating and Air Conditioning Manual																								V																											V	V				
K	2006	ALL	Body	Instrument Panel Cluster																V	V							V																																
K	2006	ALL	Body	Passenger Door Module																																																					V	V		
K	2006	ALL	Body	Passenger Presence System																																																							V	
K	2006	ALL	Body	Base Radio																																																								
K	2006	ALL	Body	Uplevel Radio																																																								
K	2006	ALL	Body	Navigation Radio																																																								
K	2006	ALL	Body	Rear Aux. Climate Module																								V																											V					V
K	2006	ALL	Body	Rear HVAC																																																								
K	2006	ALL	Body	Rear Seat Audio																																																								
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																								
K	2006	ALL	Body	Vehicle Theft Deterrent																																																								
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																								
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module											V																																													
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																		
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module					V						V																																													
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																		
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V	V																																													
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																		
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																													
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																													
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																		
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																													
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module											V																																													
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V	V																																													
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																		
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																													
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																		
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Sierra	Chassis	Electronic Suspension Control																																																									
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																									
K	2007	Sierra	Body	Amplifier (Bose)																																																									
K	2007	Sierra	Body	Body Control Module																																																									
K	2007	Sierra	Body	Body Control Module (aux.)																																																									
K	2007	Sierra	Body	Digital Radio Receiver																																																									
K	2007	Sierra	Body	Driver Door Switch																																																									
K	2007	Sierra	Body	HVAC Control Module Auto									V																																															
K	2007	Sierra	Body	HVAC Control Module Manual																																																									
K	2007	Sierra	Body	Instrument Panel Cluster																																																									
K	2007	Sierra	Body	Memory Seat Module																																																									
K	2007	Sierra	Body	Park Assist Module																																																									
K	2007	Sierra	Body	Passenger Door Switch																																																									
K	2007	Sierra	Body	Passenger Presence System																																																									
K	2007	Sierra	Body	Radio																																																									
K	2007	Sierra	Body	Rear Heated Seat Module																																																									
K	2007	Sierra	Body	Rear HVAC/RSA																																																									
K	2007	Sierra	Body	Rollover Sensor																																																									
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																																									
K	2007	Sierra	Body	Theft Deterrent Module																																																									
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																														
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																		
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																									
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																													
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																														
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																		
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																									
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																									
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Yukon	Chassis	Electronic Suspension Control																																																									
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																									
K	2007	Yukon	Body	Amplifier (Bose)																																																									
K	2007	Yukon	Body	Assist Step Controller																																																									
K	2007	Yukon	Body	Body Control Module																																																									
K	2007	Yukon	Body	Body Control Module (aux.)																																																									
K	2007	Yukon	Body	Digital Radio Receiver																																																									
K	2007	Yukon	Body	Driver Door Switch																																																									
K	2007	Yukon	Body	HVAC Control Module Auto									V																																															
K	2007	Yukon	Body	HVAC Control Module Manual																																																									
K	2007	Yukon	Body	Instrument Panel Cluster																																																									
K	2007	Yukon	Body	Lift Gate Module																																																									
K	2007	Yukon	Body	Memory Seat Module																																																									
K	2007	Yukon	Body	Park Assist Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2007	Yukon	Body	Passenger Door Switch																																																									
K	2007	Yukon	Body	Passenger Presence System																																																									
K	2007	Yukon	Body	Radio																																																									
K	2007	Yukon	Body	Rear Heated Seat Module																																																									
K	2007	Yukon	Body	Rear HVAC/RSA																																																									
K	2007	Yukon	Body	Rollover Sensor																																																									
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																																									
K	2007	Yukon	Body	Theft Deterrent Module																																																									
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module					V						V																																															
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																				
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																															
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V	V																																															
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																				
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																															
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V	V																																															
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																				
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V	V																																															
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																				
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2007	Yukon XL	Body	Amplifier (Bose)																																																										
K	2007	Yukon XL	Body	Assist Step Controller																																																										
K	2007	Yukon XL	Body	Body Control Module																																																										
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2007	Yukon XL	Body	Digital Radio Receiver																																																										
K	2007	Yukon XL	Body	Driver Door Switch																																																										
K	2007	Yukon XL	Body	HVAC Control Module Auto									V																																																	
K	2007	Yukon XL	Body	HVAC Control Module Manual																																																										
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2007	Yukon XL	Body	Lift Gate Module																																																										
K	2007	Yukon XL	Body	Memory Seat Module																																																										
K	2007	Yukon XL	Body	Park Assist Module																																																										
K	2007	Yukon XL	Body	Passenger Door Switch																																																										
K	2007	Yukon XL	Body	Passenger Presence System																																																										
K	2007	Yukon XL	Body	Radio																																																										
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2007	Yukon XL	Body	Rollover Sensor																																																										
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2007	Yukon XL	Body	Theft Deterrent Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																																

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																		
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V	V	V																																		
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																														
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																		
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																													
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																														
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																		
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																													
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module											V																																													
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																		
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																		
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																								
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																								
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2008	Sierra	Chassis	Electronic Suspension Control																																																								
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																								
K	2008	Sierra	Body	Amplifier (Bose)																																																								
K	2008	Sierra	Body	Body Control Module																																																								
K	2008	Sierra	Body	Body Control Module (aux.)																																																								
K	2008	Sierra	Body	Digital Radio Receiver																																																								
K	2008	Sierra	Body	Driver Door Switch																																																								
K	2008	Sierra	Body	HVAC Control Module Auto									V																																															
K	2008	Sierra	Body	HVAC Control Module Manual																																																								
K	2008	Sierra	Body	Instrument Panel Cluster																																																								
K	2008	Sierra	Body	Memory Seat Module																																																								
K	2008	Sierra	Body	Park Assist Module																																																								
K	2008	Sierra	Body	Passenger Door Switch																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2008	Sierra	Body	Passenger Presence System																																																								
K	2008	Sierra	Body	Radio																																																								
K	2008	Sierra	Body	Rear Heated Seat Module																																																								
K	2008	Sierra	Body	Rear HVAC/RSA																																																								
K	2008	Sierra	Body	Rollover Sensor																																																								
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																																								
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																								
K	2008	Sierra	Body	Theft Deterrent Module																																																								
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																														
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module											V																																													
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																				V	V	V																																		
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																													
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																								
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																		
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2008	Yukon	Chassis	Electronic Brake Control Module																																																								
K	2008	Yukon	Chassis	Electronic Suspension Control																																																								
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																								
K	2008	Yukon	Body	Amplifier (Bose)																																																								
K	2008	Yukon	Body	Assist Step Controller																																																								
K	2008	Yukon	Body	Body Control Module																																																								
K	2008	Yukon	Body	Body Control Module (aux.)																																																								
K	2008	Yukon	Body	Digital Radio Receiver																																																								
K	2008	Yukon	Body	Driver Door Switch																																																								
K	2008	Yukon	Body	HVAC Control Module Auto									V																																															
K	2008	Yukon	Body	HVAC Control Module Manual																																																								
K	2008	Yukon	Body	Instrument Panel Cluster																																																								
K	2008	Yukon	Body	Lift Gate Module																																																								
K	2008	Yukon	Body	Memory Seat Module																																																								
K	2008	Yukon	Body	Park Assist Module																																																								
K	2008	Yukon	Body	Passenger Door Switch																																																								
K	2008	Yukon	Body	Passenger Presence System																																																								
K	2008	Yukon	Body	Radio																																																								
K	2008	Yukon	Body	Rear Heated Seat Module																																																								
K	2008	Yukon	Body	Rear HVAC/RSA																																																								
K	2008	Yukon	Body	Rollover Sensor																																																								
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																																								
K	2008	Yukon	Body	Theft Deterrent Module																																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																									
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																									
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																									
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																									
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																									
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																									
K	2008	Yukon Hybrid	Body	Body Control Module																																																									
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																									
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																									
K	2008	Yukon Hybrid	Body	Driver Door Switch																																																									
K	2008	Yukon Hybrid	Body	HVAC Control Module									V																																															
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																									
K	2008	Yukon Hybrid	Body	Lift Gate Module																																																									
K	2008	Yukon Hybrid	Body	Memory Seat Module																																																									
K	2008	Yukon Hybrid	Body	Park Assist Module																																																									
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																																									
K	2008	Yukon Hybrid	Body	Passenger Presence System																																																									
K	2008	Yukon Hybrid	Body	Radio																																																									
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																									
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																									
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																															
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																									
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																				V	V	V																																		
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																									
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module											V																																													
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																									
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																														
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																									
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																				V	V	V																																		
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																									
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module											V																																													
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																									
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																									
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																				V	V	V																																		
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																				V	V	V																																		
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																									
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																								
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																								
K	2008	Yukon XL	Body	Amplifier (Bose)																																																								
K	2008	Yukon XL	Body	Assist Step Controller																																																								
K	2008	Yukon XL	Body	Body Control Module																																																								
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																								
K	2008	Yukon XL	Body	Digital Radio Receiver																																																								
K	2008	Yukon XL	Body	Driver Door Switch																																																								
K	2008	Yukon XL	Body	HVAC Control Module Auto									V																																															
K	2008	Yukon XL	Body	HVAC Control Module Manual																																																								
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																								
K	2008	Yukon XL	Body	Lift Gate Module																																																								
K	2008	Yukon XL	Body	Memory Seat Module																																																								
K	2008	Yukon XL	Body	Park Assist Module																																																								
K	2008	Yukon XL	Body	Passenger Door Switch																																																								
K	2008	Yukon XL	Body	Passenger Presence System																																																								
K	2008	Yukon XL	Body	Radio																																																								
K	2008	Yukon XL	Body	Rear Heated Seat Module																																																								
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																								
K	2008	Yukon XL	Body	Rollover Sensor																																																								
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
K	2008	Yukon XL	Body	Theft Deterrent Module																																																								
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																														
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																														
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																								
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul																																																								
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																														
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																								
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																								
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																									
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																									
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																									
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																									
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																									
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																									
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																									
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																									
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																									
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
K	2009	Sierra	Chassis	Electronic Suspension Control																																																									
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																									
K	2009	Sierra	Body	Amplifier (Bose)																																																									
K	2009	Sierra	Body	Body Control Module																																																								
K	2009	Sierra	Body	Body Control Module (aux.)																																																								
K	2009	Sierra	Body	Digital Radio Receiver																																																								
K	2009	Sierra	Body	Driver Door Switch																																																								
K	2009	Sierra	Body	HVAC Control Module Auto									V																																															
K	2009	Sierra	Body	HVAC Control Module Manual																																																									
K	2009	Sierra	Body	Instrument Panel Cluster																																																									
K	2009	Sierra	Body	Memory Seat Module																																																									
K	2009	Sierra	Body	Park Assist Module																																																									
K	2009	Sierra	Body	Passenger Door Switch																																																									
K	2009	Sierra	Body	Passenger Presence System																																																									
K	2009	Sierra	Body	Radio																																																									
K	2009	Sierra	Body	Rear Heated Seat Module																																																									
K	2009	Sierra	Body	Rear HVAC/RSA																																																									
K	2009	Sierra	Body	Rollover Sensor																																																									
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																																									
K	2009	Sierra	Body	Theft Deterrent Module																																																									
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																				
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																									
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																									
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																									
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																									
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																									
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																									
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																									
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																									
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																									
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																									
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																									
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																									
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																										
K	2009	Sierra Hybrid	Body	Body Control Module																																																										
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																										
K	2009	Sierra Hybrid	Body	Driver Door Switch																																																										
K	2009	Sierra Hybrid	Body	HVAC Control Module									V																																																	
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
K	2009	Sierra Hybrid	Body	Memory Seat Module																																																										
K	2009	Sierra Hybrid	Body	Park Assist Module																																																										
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																																										
K	2009	Sierra Hybrid	Body	Passenger Presence System																																																										
K	2009	Sierra Hybrid	Body	Radio																																																										
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
K	2009	Sierra Hybrid	Body	Rollover Sensor																																																										
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																																
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																										
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2009	Yukon	Chassis	Electronic Brake Control Module																																																										
K	2009	Yukon	Chassis	Electronic Suspension Control																																																										
K	2009	Yukon	Chassis	Trailer Brake Control Module																																																										
K	2009	Yukon	Body	Amplifier (Bose)																																																										
K	2009	Yukon	Body	Assist Step Controller																																																										
K	2009	Yukon	Body	Body Control Module																																																										
K	2009	Yukon	Body	Body Control Module (aux.)																																																										
K	2009	Yukon	Body	Digital Radio Receiver																																																										
K	2009	Yukon	Body	Driver Door Switch																																																										
K	2009	Yukon	Body	HVAC Control Module Auto									V																																																
K	2009	Yukon	Body	HVAC Control Module Manual																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2009	Yukon	Body	Instrument Panel Cluster																																																								
K	2009	Yukon	Body	Left Side Object Detection Module																																																								
K	2009	Yukon	Body	Lift Gate Module																																																								
K	2009	Yukon	Body	Memory Seat Module																																																								
K	2009	Yukon	Body	Park Assist Module																																																								
K	2009	Yukon	Body	Passenger Door Switch																																																								
K	2009	Yukon	Body	Passenger Presence System																																																								
K	2009	Yukon	Body	Radio																																																								
K	2009	Yukon	Body	Rear Heated Seat Module																																																								
K	2009	Yukon	Body	Rear HVAC/RSA																																																								
K	2009	Yukon	Body	Right Side Object Detection Module																																																								
K	2009	Yukon	Body	Rollover Sensor																																																								
K	2009	Yukon	Body	Supplemental Inflatable Restraint																																																								
K	2009	Yukon	Body	Theft Deterrent Module																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module					V																																																			
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																								
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																								
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																								
K	2009	Yukon Hybrid	Body	Body Control Module																																																								
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																								
K	2009	Yukon Hybrid	Body	Driver Door Switch																																																								
K	2009	Yukon Hybrid	Body	Heated Seat Module																																																								
K	2009	Yukon Hybrid	Body	HVAC Control Module									V																																														
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
K	2009	Yukon Hybrid	Body	Park Assist Module																																																								
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																																								
K	2009	Yukon Hybrid	Body	Passenger Presence System																																																								
K	2009	Yukon Hybrid	Body	Radio																																																								
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
K	2009	Yukon Hybrid	Body	Rollover Sensor																																																								
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																								
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module										V																																													
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																								
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																								
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																								
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																								
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																								
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module										V																																														
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																								
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																								
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																														
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																								
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																								
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																								
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																								
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																								
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																								
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																								
K	2009	Yukon XL	Body	Amplifier (Bose)																																																								
K	2009	Yukon XL	Body	Assist Step Controller																																																								
K	2009	Yukon XL	Body	Body Control Module																																																								
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																								
K	2009	Yukon XL	Body	Digital Radio Receiver																																																								
K	2009	Yukon XL	Body	Driver Door Switch																																																								
K	2009	Yukon XL	Body	HVAC Control Module Auto									V																																														
K	2009	Yukon XL	Body	HVAC Control Module Manual																																																								
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																								
K	2009	Yukon XL	Body	Left Side Object Detection Module																																																								
K	2009	Yukon XL	Body	Lift Gate Module																																																								
K	2009	Yukon XL	Body	Memory Seat Module																																																								
K	2009	Yukon XL	Body	Park Assist Module																																																								
K	2009	Yukon XL	Body	Passenger Door Switch																																																								
K	2009	Yukon XL	Body	Passenger Presence System																																																								
K	2009	Yukon XL	Body	Radio																																																								
K	2009	Yukon XL	Body	Rear Heated Seat Module																																																								
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																								
K	2009	Yukon XL	Body	Right Side Object Detection Module																																																								
K	2009	Yukon XL	Body	Rollover Sensor																																																								
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
K	2009	Yukon XL	Body	Theft Deterrent Module																																																								
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																		
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																						V																		
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																						V																		

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2010	Sierra	Chassis	Electronic Suspension Control																																																										
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Sierra	Body	Amplifier (Bose)																																																										
K	2010	Sierra	Body	Body Control Module																																																									
K	2010	Sierra	Body	Body Control Module (aux.)																																																										
K	2010	Sierra	Body	Digital Radio Receiver																																																										
K	2010	Sierra	Body	Driver Door Switch																																																										
K	2010	Sierra	Body	HVAC Control Module Auto									V																																																
K	2010	Sierra	Body	HVAC Control Module Manual									V																																																
K	2010	Sierra	Body	Instrument Panel Cluster																																																										
K	2010	Sierra	Body	Memory Seat Module																																																										
K	2010	Sierra	Body	Park Assist Module																																																										
K	2010	Sierra	Body	Passenger Door Switch																																																										
K	2010	Sierra	Body	Passenger Presence System																																																										
K	2010	Sierra	Body	Radio																																																										
K	2010	Sierra	Body	Rear Heated Seat Module																																																										
K	2010	Sierra	Body	Rear HVAC/RSA																																																										
K	2010	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2010	Sierra	Body	Theft Deterrent Module																																																										
K	2010	Sierra Hybrid	Powertrain	Engine Control Module					V																																																				
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																								
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																								
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																								
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																								
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																								
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																								
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																								
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																								
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																								
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																								
K	2010	Sierra Hybrid	Body	Body Control Module																																																								
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																								
K	2010	Sierra Hybrid	Body	Driver Door Switch																																																								
K	2010	Sierra Hybrid	Body	Heated Seat Module																																																								
K	2010	Sierra Hybrid	Body	HVAC Control Module																																																								
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
K	2010	Sierra Hybrid	Body	Park Assist Module																																																								
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																																								
K	2010	Sierra Hybrid	Body	Passenger Presence System																																																								
K	2010	Sierra Hybrid	Body	Radio																																																								
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																								
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																														
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																								
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																								
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																								
K	2010	Yukon	Chassis	Electronic Brake Control Module																																																								
K	2010	Yukon	Chassis	Electronic Suspension Control																																																								
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Yukon	Body	Amplifier (Bose)																																																								
K	2010	Yukon	Body	Assist Step Controller																																																								
K	2010	Yukon	Body	Body Control Module																																																								
K	2010	Yukon	Body	Body Control Module (aux.)																																																								
K	2010	Yukon	Body	Digital Radio Receiver																																																								
K	2010	Yukon	Body	Driver Door Switch																																																								
K	2010	Yukon	Body	HVAC Control Module Auto									V																																															
K	2010	Yukon	Body	HVAC Control Module Manual																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2010	Yukon	Body	Instrument Panel Cluster																																																								
K	2010	Yukon	Body	Left Side Object Detection Module																																																								
K	2010	Yukon	Body	Lift Gate Module																																																								
K	2010	Yukon	Body	Memory Seat Module																																																								
K	2010	Yukon	Body	Park Assist Module																																																								
K	2010	Yukon	Body	Passenger Door Switch																																																								
K	2010	Yukon	Body	Passenger Presence System																																																								
K	2010	Yukon	Body	Radio																																																								
K	2010	Yukon	Body	Rear Heated Seat Module																																																								
K	2010	Yukon	Body	Rear HVAC/RSA																																																								
K	2010	Yukon	Body	Right Side Object Detection Module																																																								
K	2010	Yukon	Body	Supplemental Inflatable Restraint																																																								
K	2010	Yukon	Body	Theft Deterrent Module																																																								
K	2010	Yukon Hybrid	Powertrain	Engine Control Module					V																																																			
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																								
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																								
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																								
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																								
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																								
K	2010	Yukon Hybrid	Body	Body Control Module																																																								
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																								
K	2010	Yukon Hybrid	Body	Driver Door Switch																																																								
K	2010	Yukon Hybrid	Body	Heated Seat Module																																																								
K	2010	Yukon Hybrid	Body	HVAC Control Module																																																								
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
K	2010	Yukon Hybrid	Body	Lift Gate Module																																																								
K	2010	Yukon Hybrid	Body	Park Assist Module																																																								
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																																								
K	2010	Yukon Hybrid	Body	Passenger Presence System																																																								
K	2010	Yukon Hybrid	Body	Radio																																																								
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																								
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																								
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																																
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																																
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																										
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																										
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																										
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																										
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2010	Yukon XL	Body	Amplifier (Bose)																																																										
K	2010	Yukon XL	Body	Assist Step Controller																																																										
K	2010	Yukon XL	Body	Body Control Module																																																										
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2010	Yukon XL	Body	Digital Radio Receiver																																																										
K	2010	Yukon XL	Body	Driver Door Switch																																																										
K	2010	Yukon XL	Body	HVAC Control Module Auto									V																																																
K	2010	Yukon XL	Body	HVAC Control Module Manual																																																										
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2010	Yukon XL	Body	Left Side Object Detection Module																																																										
K	2010	Yukon XL	Body	Lift Gate Module																																																										
K	2010	Yukon XL	Body	Memory Seat Module																																																										
K	2010	Yukon XL	Body	Park Assist Module																																																										
K	2010	Yukon XL	Body	Passenger Door Switch																																																										
K	2010	Yukon XL	Body	Passenger Presence System																																																										
K	2010	Yukon XL	Body	Radio																																																										
K	2010	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2010	Yukon XL	Body	Right Side Object Detection Module																																																										
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2010	Yukon XL	Body	Theft Deterrent Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																						
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
L	2004	ALL	Chassis	4WAL 3 Sensor																																																										
L	2004	ALL	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2004	ALL	Body	Instrument Panel Cluster																																																									
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																					
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
L	2005	ALL	Chassis	4WAL 3 Sensor																																																									
L	2005	ALL	Body	Body Control Module																																																									
L	2005	ALL	Body	Instrument Panel Cluster																																																									
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																									
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																									
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																									
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																									
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																									
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																									
L	2010	Terrain	Chassis	Electronic Brake Control Module																																																									
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2010	Terrain	Body	Body Control Module																																																									
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2010	Terrain	Body	Passenger Presence Module																																																									
L	2010	Terrain	Body	Instrument Cluster																																																									
L	2010	Terrain	Body	Radio																																																									
L	2010	Terrain	Body	Multimedia Player Interface Module																																																									
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																																									
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																									
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																									
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																																									
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																																									
L	2010	Terrain	Body	Liftgate Control Module																																																									
L	2010	Terrain	Body	Parking Assist Control Module																																																									
L	2010	Terrain	Body	Frontview Camera Module																																																									
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																																									
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																																									
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																									
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																									
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																									
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																									
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																									
L	2011	Terrain	Chassis	Electronic Brake Control Module																																																									
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2011	Terrain	Body	Body Control Module																																																									
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2011	Terrain	Body	Passenger Presence Module																																																									
L	2011	Terrain	Body	Instrument Cluster																																																									
L	2011	Terrain	Body	Radio																																																									
L	2011	Terrain	Body	Multimedia Player Interface Module																																																									
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																									
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																									
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																																									
L	2011	Terrain	Body	Liftgate Control Module																																																										
L	2011	Terrain	Body	Parking Assist Control Module																																																										
L	2011	Terrain	Body	Frontview Camera Module																																																										
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																																										
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																										
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																										
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																										
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2012	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2012	Terrain	Body	Body Control Module																																																										
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2012	Terrain	Body	Passenger Presence Module																																																										
L	2012	Terrain	Body	Instrument Cluster																																																										
L	2012	Terrain	Body	Radio																																																										
L	2012	Terrain	Body	Multimedia Player Interface Module																																																										
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2012	Terrain	Body	Liftgate Control Module																																																										
L	2012	Terrain	Body	Parking Assist Control Module																																																										
L	2012	Terrain	Body	Frontview Camera Module																																																										
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																																										
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																										
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																										
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																										
L	2013	Terrain	Chassis	Electronic Brake Control Module																																																										
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																										
L	2013	Terrain	Chassis	Power Steering Control Module																																																										
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																										
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																																										
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																										
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
L	2013	Terrain	Body	Passenger Presence Module																																																										
L	2013	Terrain	Body	Instrument Cluster																																																										
L	2013	Terrain	Body	Radio																																																										
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																										
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																										
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																																										
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																																										
L	2013	Terrain	Body	Liftgate Control Module																																																										
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																										
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																										
L	2013	Terrain	Body	Parking Assist Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2013	Terrain	Body	Frontview Camera Module																																																								
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																								
L	2014	Terrain	Chassis	Electronic Brake Control Module																																																								
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2014	Terrain	Chassis	Power Steering Control Module																																																								
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																																								
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																								
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2014	Terrain	Body	Passenger Presence Module																																																								
L	2014	Terrain	Body	Instrument Cluster																																																								
L	2014	Terrain	Body	Radio																																																								
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																								
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																								
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																																								
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																																								
L	2014	Terrain	Body	Liftgate Control Module																																																								
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																								
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																								
L	2014	Terrain	Body	Parking Assist Control Module																																																								
L	2014	Terrain	Body	Frontview Camera Module																																																								
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																								
L	2015	Terrain	Chassis	Electronic Brake Control Module																																																								
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																								
L	2015	Terrain	Chassis	Power Steering Control Module																																																								
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																								
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																																								
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																								
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
L	2015	Terrain	Body	Passenger Presence Module																																																								
L	2015	Terrain	Body	Instrument Cluster																																																								
L	2015	Terrain	Body	Radio																																																								
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																																								
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																																								
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																																								
L	2015	Terrain	Body	Liftgate Control Module																																																								
L	2015	Terrain	Body	Seat Memory Control Module																																																								
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																								
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																								
L	2015	Terrain	Body	Parking Assist Control Module																																																								
L	2015	Terrain	Body	Frontview Camera Module																																																								
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																								
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																									
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																									
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																									
L	2016	Terrain	Chassis	Electronic Brake Control Module																																																									
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																									
L	2016	Terrain	Chassis	Power Steering Control Module																																																									
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																									
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																																									
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																									
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
L	2016	Terrain	Body	Passenger Presence Module																																																									
L	2016	Terrain	Body	Instrument Cluster																																																									
L	2016	Terrain	Body	Radio																																																									
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																																									
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																									
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																																									
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																																									
L	2016	Terrain	Body	Liftgate Control Module																																																V									
L	2016	Terrain	Body	Seat Memory Control Module																																																									
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																									
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																									
L	2016	Terrain	Body	Parking Assist Control Module																																																									
L	2016	Terrain	Body	Frontview Camera Module																																																									
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																					
M	2004	ALL	Chassis	4WAL 3 Sensor																																																									
M	2004	ALL	Body	Body Control Module																																																								
M	2004	ALL	Body	Instrument Panel Cluster																																																								
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																								
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
M	2005	ALL	Chassis	4WAL 3 Sensor																																																								
M	2005	ALL	Body	Body Control Module																																																								
M	2005	ALL	Body	Instrument Panel Cluster																																																								
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																								
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																								
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
P	2007	ALL	Body	Theft Deterrent Module																																																								
R	2007	ALL	Powertrain	Engine Control Module																																																								
R	2007	ALL	Powertrain	Transmission Control Module																																																								
R	2007	ALL	Chassis	Electronic Brake Control Module																																																								
R	2007	ALL	Body	Body Control Module																																																								
R	2007	ALL	Body	Digital Radio Receiver																																																								
R	2007	ALL	Body	Driver Door Switch																																																								
R	2007	ALL	Body	Head Up Display																																																								
R	2007	ALL	Body	Heated Seat Module																																																								
R	2007	ALL	Body	HVAC Control Module Auto																																																								
R	2007	ALL	Body	HVAC Control Module Manual																																																								
R	2007	ALL	Body	Instrument Panel Cluster																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2007	ALL	Body	Lift Gate Module																																																								
R	2007	ALL	Body	Park Assist Module																																																								
R	2007	ALL	Body	Passenger Door Switch																																																								
R	2007	ALL	Body	Passenger Presence System																																																								
R	2007	ALL	Body	Radio																																																								
R	2007	ALL	Body	Rear HVAC/RSA																																																								
R	2007	ALL	Body	Rollover Sensor																																																								
R	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2007	ALL	Body	Theft Deterrent Module																																																								
R	2008	ALL	Powertrain	Engine Control Module																																																								
R	2008	ALL	Powertrain	Transmission Control Module																																																								
R	2008	ALL	Chassis	Electronic Brake Control Module																																																								
R	2008	ALL	Body	Body Control Module																																																								
R	2008	ALL	Body	Digital Radio Receiver																																																								
R	2008	ALL	Body	Driver Door Switch																																																								
R	2008	ALL	Body	Head Up Display																																																								
R	2008	ALL	Body	Heated Seat Module																																																								
R	2008	ALL	Body	HVAC Control Module Auto																																																								
R	2008	ALL	Body	HVAC Control Module Manual																																																								
R	2008	ALL	Body	Instrument Panel Cluster																																																								
R	2008	ALL	Body	Lift Gate Module																																																								
R	2008	ALL	Body	Park Assist Module																																																								
R	2008	ALL	Body	Passenger Door Switch																																																								
R	2008	ALL	Body	Passenger Presence System																																																								
R	2008	ALL	Body	Radio																																																								
R	2008	ALL	Body	Rear HVAC/RSA																																																								
R	2008	ALL	Body	Rollover Sensor																																																								
R	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2008	ALL	Body	Theft Deterrent Module																																																								
R	2009	ALL	Powertrain	Engine Control Module																																																								
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2009	ALL	Powertrain	Transmission Control Module																																																								
R	2009	ALL	Chassis	Electronic Brake Control Module																																																								
R	2009	ALL	Body	Body Control Module																																																								
R	2009	ALL	Body	Digital Radio Receiver																																																								
R	2009	ALL	Body	Driver Door Switch																																																								
R	2009	ALL	Body	Head Up Display																																																								
R	2009	ALL	Body	Heated Seat Module																																																								
R	2009	ALL	Body	HVAC Control Module Auto																																																								
R	2009	ALL	Body	HVAC Control Module Manual																																																								
R	2009	ALL	Body	Instrument Panel Cluster																																																								
R	2009	ALL	Body	Lift Gate Module																																																								
R	2009	ALL	Body	Park Assist Module																																																								
R	2009	ALL	Body	Passenger Door Switch																																																								
R	2009	ALL	Body	Passenger Presence System																																																								
R	2009	ALL	Body	Radio																																																								
R	2009	ALL	Body	Rear HVAC/RSA																																																								
R	2009	ALL	Body	Rollover Sensor																																																								
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2009	ALL	Body	Theft Deterrent Module																																																								
R	2010	ALL	Powertrain	Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2010	ALL	Powertrain	Transmission Control Module																																																								
R	2010	ALL	Chassis	Electronic Brake Control Module																																																								
R	2010	ALL	Body	Body Control Module																																																								
R	2010	ALL	Body	Digital Radio Receiver																																																								
R	2010	ALL	Body	Driver Door Switch																																																								
R	2010	ALL	Body	Head Up Display																																																								
R	2010	ALL	Body	Heated Seat Module																																																								
R	2010	ALL	Body	HVAC Control Module Auto									V																																															
R	2010	ALL	Body	HVAC Control Module Manual																																																								
R	2010	ALL	Body	Instrument Panel Cluster																																																								
R	2010	ALL	Body	Lift Gate Module																																																								
R	2010	ALL	Body	Park Assist Module																																																								
R	2010	ALL	Body	Passenger Door Switch																																																								
R	2010	ALL	Body	Passenger Presence System																																																								
R	2010	ALL	Body	Radio																																																								
R	2010	ALL	Body	Rear HVAC/RSA																																																								
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2010	ALL	Body	Theft Deterrent Module																																																								
R	2011	ALL	Powertrain	Engine Control Module																																																								
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2011	ALL	Powertrain	Transmission Control Module																																																								
R	2011	ALL	Chassis	Electronic Brake Control Module																																																								
R	2011	ALL	Body	Body Control Module																																																								
R	2011	ALL	Body	Digital Radio Receiver																																																								
R	2011	ALL	Body	Driver Door Switch																																																								
R	2011	ALL	Body	Head Up Display																																																								
R	2011	ALL	Body	Heated Seat Module																																																								
R	2011	ALL	Body	HVAC Control Module Auto									V																																															
R	2011	ALL	Body	HVAC Control Module Manual																																																								
R	2011	ALL	Body	Instrument Panel Cluster																																																								
R	2011	ALL	Body	Lift Gate Module																																																								
R	2011	ALL	Body	Park Assist Module																																																								
R	2011	ALL	Body	Passenger Door Switch																																																								
R	2011	ALL	Body	Passenger Presence System																																																								
R	2011	ALL	Body	Radio																																																								
R	2011	ALL	Body	Rear HVAC/RSA																																																								
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
R	2011	ALL	Body	Theft Deterrent Module																																																								
R	2012	ALL	Powertrain	Engine Control Module																																																								
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																								
R	2012	ALL	Powertrain	Transmission Control Module																																																								
R	2012	ALL	Chassis	Electronic Brake Control Module																																																								
R	2012	ALL	Body	Body Control Module																																																								
R	2012	ALL	Body	Digital Radio Receiver																																																								
R	2012	ALL	Body	Driver Door Switch																																																								
R	2012	ALL	Body	Head Up Display																																																								
R	2012	ALL	Body	Heated Seat Module																																																								
R	2012	ALL	Body	HVAC Control Module Auto									V																																															
R	2012	ALL	Body	HVAC Control Module Manual																																																								
R	2012	ALL	Body	Instrument Panel Cluster																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2012	ALL	Body	Lift Gate Module																																																									
R	2012	ALL	Body	Park Assist Module																																																									
R	2012	ALL	Body	Passenger Door Switch																																																									
R	2012	ALL	Body	Passenger Presence System																																																									
R	2012	ALL	Body	Radio																																																									
R	2012	ALL	Body	Rear HVAC/RSA																																																									
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2012	ALL	Body	Theft Deterrent Module																																																									
R	2013	ALL	Powertrain	Engine Control Module																																																									
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																									
R	2013	ALL	Powertrain	Transmission Control Module																																																									
R	2013	ALL	Chassis	Electronic Brake Control Module																																																									
R	2013	ALL	Body	Body Control Module																																																									
R	2013	ALL	Body	Digital Radio Receiver																																																									
R	2013	ALL	Body	Driver Door Switch																																																									
R	2013	ALL	Body	Head Up Display																																																									
R	2013	ALL	Body	Heated Seat Module																																																									
R	2013	ALL	Body	HVAC Control Module Auto									V																																																
R	2013	ALL	Body	HVAC Control Module Manual																																																										
R	2013	ALL	Body	Instrument Panel Cluster																																																									
R	2013	ALL	Body	Left Side Object Detection Module																																																									
R	2013	ALL	Body	Lift Gate Module																																																									
R	2013	ALL	Body	Park Assist Module																																																									
R	2013	ALL	Body	Passenger Door Switch																																																									
R	2013	ALL	Body	Passenger Presence System																																																									
R	2013	ALL	Body	Radio																																																									
R	2013	ALL	Body	Rear HVAC/RSA																																																									
R	2013	ALL	Body	Right Side Object Detection Module																																																									
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
R	2013	ALL	Body	Theft Deterrent Module																																																									
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
R	2014	Acadia	Powertrain	Chassis Control Module																																																									
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																									
R	2014	Acadia	Chassis	Electronic Brake Control Module																																													V											
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																									
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																									
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
R	2014	Acadia	Body	Passenger Presence Module																																																									
R	2014	Acadia	Body	Instrument Cluster																																																									
R	2014	Acadia	Body	Head-Up Display Module																																																									
R	2014	Acadia	Body	Radio																																																									
R	2014	Acadia	Body	Rear Audio Control Module																																																									
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																									
R	2014	Acadia	Body	Personal Audio Link Control Module																																																									
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																									
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																									
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																									
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																									
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2014	Acadia	Body	Liftgate Control Module																																																								
R	2014	Acadia	Body	Seat Memory Control Module																																																								
R	2014	Acadia	Body	Front Seat Heating Control Module																																																								
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																								
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																								
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																								
R	2014	Acadia	Body	Parking Assist Control Module																																																								
R	2014	Acadia	Body	Frontview Camera Module																																																								
R	2014	Acadia	Body	Theft Deterrent Module																																																								
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																								
R	2015	Acadia	Chassis	Electronic Brake Control Module																																													V											
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																								
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																								
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2015	Acadia	Body	Passenger Presence Module																																																								
R	2015	Acadia	Body	Instrument Cluster																																																								
R	2015	Acadia	Body	Head-Up Display Module																																																								
R	2015	Acadia	Body	Radio																																																								
R	2015	Acadia	Body	Rear Audio Control Module																																																								
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																								
R	2015	Acadia	Body	Personal Audio Link Control Module																																														V											
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																								
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																								
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																								
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																								
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																								
R	2015	Acadia	Body	Liftgate Control Module																																																								
R	2015	Acadia	Body	Seat Memory Control Module																																																								
R	2015	Acadia	Body	Front Seat Heating Control Module																																																								
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																								
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																								
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																								
R	2015	Acadia	Body	Parking Assist Control Module																																																								
R	2015	Acadia	Body	Frontview Camera Module																																																								
R	2015	Acadia	Body	Theft Deterrent Module																																																								
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																								
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																								
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																								
R	2016	Acadia	Chassis	Electronic Brake Control Module																																													V											
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																								
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																								
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
R	2016	Acadia	Body	Passenger Presence Module																																																								
R	2016	Acadia	Body	Instrument Cluster																																																								
R	2016	Acadia	Body	Head-Up Display Module																																																								
R	2016	Acadia	Body	Radio																																																								
R	2016	Acadia	Body	Rear Audio Control Module																																																								
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
R	2016	Acadia	Body	Personal Audio Link Control Module																																														V									
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																							
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																							
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																							
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																							
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																							
R	2016	Acadia	Body	Liftgate Control Module																																																							
R	2016	Acadia	Body	Seat Memory Control Module																																																							
R	2016	Acadia	Body	Front Seat Heating Control Module																																																							
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																							
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																							
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																							
R	2016	Acadia	Body	Parking Assist Control Module																																																							
R	2016	Acadia	Body	Frontview Camera Module																																																							
R	2016	Acadia	Body	Theft Deterrent Module																																																							
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																							
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																							
S	2004	Sonoma	Body	Body Control Module																																																						
S	2004	Sonoma	Body	Instrument Panel Cluster																																																						
S	2004	Sonoma	Body	Base Radio																																																						
S	2004	Sonoma	Body	Uplevel Radio																																																						
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																						
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																						
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																				V																																			
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																						
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																				V																																			
S	2004	Canyon	Chassis	ABS Without Traction Control																																																						
S	2004	Canyon	Chassis	ABS With Traction Control																																																						
S	2004	Canyon	Body	Body Control Module																																																					
S	2004	Canyon	Body	Instrument Panel Cluster																																																						
S	2004	Canyon	Body	OnStar																																																					
S	2004	Canyon	Body	Base Radio																																																					
S	2004	Canyon	Body	Uplevel Radio																																																					
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																																					
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																					
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																			
S	2004	Envoy	Chassis	ABS Without Traction Control																																																					
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																					
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																					
S	2004	Envoy	Body	Amplifier (Bose)																																																					
S	2004	Envoy	Body	Body Control Module																																																					
S	2004	Envoy	Body	Driver Door Module																																																					
S	2004	Envoy	Body	Driver Seat Module																								V																								V						
S	2004	Envoy	Body	Heating and Air Conditioning Auto																								V																									V	V				
S	2004	Envoy	Body	Heating and Air Conditioning Manual																								V																									V	V				
S	2004	Envoy	Body	Instrument Panel Cluster																V	V							V																														
S	2004	Envoy	Body	Lift Gate Module																																																					
S	2004	Envoy	Body	OnStar																																																					
S	2004	Envoy	Body	Passenger Door Module																																																					

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2004	Envoy	Body	Uplevel Radio																																																										
S	2004	Envoy	Body	Navigation Radio																																																										
S	2004	Envoy	Body	Rear Seat Audio																																																										
S	2004	Envoy	Body	Rear Seat Entertainment																																																										
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																						
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																				V																																						
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy XL	Body	Amplifier (Bose)																																																										
S	2004	Envoy XL	Body	Body Control Module																																																										
S	2004	Envoy XL	Body	Driver Door Module																																																										
S	2004	Envoy XL	Body	Driver Seat Module																								V																										V								
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																								V																											V	V						
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																								V																											V	V						
S	2004	Envoy XL	Body	Instrument Panel Cluster																V	V							V																																		
S	2004	Envoy XL	Body	Lift Gate Module																																																										
S	2004	Envoy XL	Body	OnStar																																																										
S	2004	Envoy XL	Body	Passenger Door Module																																																										
S	2004	Envoy XL	Body	Uplevel Radio																																																										
S	2004	Envoy XL	Body	Navigation Radio																																																										
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																								V																												V	V					
S	2004	Envoy XL	Body	Rear HVAC Manual																								V																												V	V					
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																										
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																										
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																						
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																				V																																						
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																										
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																										
S	2004	Envoy XUV	Body	Body Control Module																																																										
S	2004	Envoy XUV	Body	Driver Door Module																																																										
S	2004	Envoy XUV	Body	Driver Seat Module																								V																										V								
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																								V																											V	V						
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																								V																											V	V						
S	2004	Envoy XUV	Body	Instrument Panel Cluster																V	V							V																																		
S	2004	Envoy XUV	Body	Lift Gate Module																																																										
S	2004	Envoy XUV	Body	OnStar																																																										
S	2004	Envoy XUV	Body	Passenger Door Module																																																										
S	2004	Envoy XUV	Body	Uplevel Radio																																																										
S	2004	Envoy XUV	Body	Navigation Radio																																																										
S	2004	Envoy XUV	Body	Rear Seat Audio																																																										
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																									
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																									
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																					
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																									
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																									
S	2004	Jimmy	Body	Body Control Module																																																									
S	2004	Jimmy	Body	Heating and Air Conditioning																																																									
S	2004	Jimmy	Body	Instrument Panel Cluster																																																									
S	2004	Jimmy	Body	Memory Seat Module																																																									
S	2004	Jimmy	Body	Base Radio																																																									
S	2004	Jimmy	Body	Uplevel Radio																																																									
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																									
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																				V																																					
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																				V																																					
S	2005	Canyon	Chassis	ABS Without Traction Control																																																									
S	2005	Canyon	Chassis	ABS With Traction Control																																																									
S	2005	Canyon	Body	Body Control Module																																																									
S	2005	Canyon	Body	Instrument Panel Cluster																																																									
S	2005	Canyon	Body	Base Radio																																																									
S	2005	Canyon	Body	Uplevel Radio																																																									
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																																									
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																																									
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																					
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																															
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																			
S	2005	Envoy	Chassis	ABS Without Traction Control																																																									
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																									
S	2005	Envoy	Body	Body Control Module																																																									
S	2005	Envoy	Body	Disc Player and Video Display																																																									
S	2005	Envoy	Body	Driver Door Module																																																									
S	2005	Envoy	Body	Driver Seat Module																								V																										V							
S	2005	Envoy	Body	Heating and Air Conditioning Auto																								V																											V	V					
S	2005	Envoy	Body	Heating and Air Conditioning Manual																								V																										V	V					
S	2005	Envoy	Body	Instrument Panel Cluster																V	V							V																																	
S	2005	Envoy	Body	Lift Gate Module																																																									
S	2005	Envoy	Body	Passenger Door Module																																																									
S	2005	Envoy	Body	Passenger Presence System																																																								V	
S	2005	Envoy	Body	Uplevel Radio																																																									
S	2005	Envoy	Body	Navigation Radio																																																									
S	2005	Envoy	Body	Rear Seat Audio																																																									
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																																									
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																																									
S	2005	Envoy	Body	Vehicle Theft Deterrent																																																									
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																					
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																															

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																			
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy XL	Body	Body Control Module																																																										
S	2005	Envoy XL	Body	Disc Player and Video Display																																																										
S	2005	Envoy XL	Body	Driver Door Module																																																										
S	2005	Envoy XL	Body	Driver Seat Module																								V																																			
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																								V																																		
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																								V																																		
S	2005	Envoy XL	Body	Instrument Panel Cluster																V	V							V																																		
S	2005	Envoy XL	Body	Lift Gate Module																																																										
S	2005	Envoy XL	Body	Passenger Door Module																																																										
S	2005	Envoy XL	Body	Passenger Presence System																																																									V	
S	2005	Envoy XL	Body	Uplevel Radio																																																										
S	2005	Envoy XL	Body	Navigation Radio																																																										
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																								V																																		
S	2005	Envoy XL	Body	Rear HVAC Manual																								V																																		
S	2005	Envoy XL	Body	Rear Seat Audio																																																										
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																										
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																						
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																				
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																										
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Envoy XUV	Body	Body Control Module																																																										
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																										
S	2005	Envoy XUV	Body	Driver Door Module																																																										
S	2005	Envoy XUV	Body	Driver Seat Module																								V																																			
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																								V																																		
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																								V																																		
S	2005	Envoy XUV	Body	Instrument Panel Cluster																V	V							V																																		
S	2005	Envoy XUV	Body	Lift Gate Module																																																										
S	2005	Envoy XUV	Body	Passenger Door Module																																																										
S	2005	Envoy XUV	Body	Passenger Presence System																																																									V	
S	2005	Envoy XUV	Body	Uplevel Radio																																																										
S	2005	Envoy XUV	Body	Navigation Radio																																																										
S	2005	Envoy XUV	Body	Rear Seat Audio																																																										
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																										
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																						
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																										
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Jimmy	Body	Body Control Module																																																										
S	2005	Jimmy	Body	Heating and Air Conditioning																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2005	Jimmy	Body	Instrument Panel Cluster																																																										
S	2005	Jimmy	Body	Memory Seat Module																																																										
S	2005	Jimmy	Body	Base Radio																																																										
S	2005	Jimmy	Body	Uplevel Radio																																																										
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																										
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																						
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																										
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Sonoma	Body	Body Control Module																																																										
S	2005	Sonoma	Body	Instrument Panel Cluster																																																										
S	2005	Sonoma	Body	Base Radio																																																										
S	2005	Sonoma	Body	Uplevel Radio																																																										
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																										
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																				V																																						
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																				V																																						
S	2006	Canyon	Chassis	ABS Without Traction Control																																																										
S	2006	Canyon	Chassis	ABS With Traction Control																																																										
S	2006	Canyon	Body	Body Control Module																																																										
S	2006	Canyon	Body	Instrument Panel Cluster																																																										
S	2006	Canyon	Body	Passenger Presence System																																																								V		
S	2006	Canyon	Body	Base Radio																																																										
S	2006	Canyon	Body	Uplevel Radio																																																										
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																						
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																															
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																			
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module										V																																															
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																			
S	2006	Envoy	Chassis	ABS/TCS/VSES																																																										
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																										
S	2006	Envoy	Body	Body Control Module																																																										
S	2006	Envoy	Body	Disc Player and Video Display																																																										
S	2006	Envoy	Body	Driver Door Module																																																										
S	2006	Envoy	Body	Driver Seat Module													V											V																																		
S	2006	Envoy	Body	Heating and Air Conditioning Auto																								V																																	
S	2006	Envoy	Body	Heating and Air Conditioning Manual																								V																																	
S	2006	Envoy	Body	Instrument Panel Cluster																V	V							V																																	
S	2006	Envoy	Body	Lift Gate Module																																																									
S	2006	Envoy	Body	Passenger Door Module																																																									
S	2006	Envoy	Body	Passenger Presence System																																																								V	
S	2006	Envoy	Body	Uplevel Radio																																																									
S	2006	Envoy	Body	Navigation Radio																																																									
S	2006	Envoy	Body	Rear Seat Audio																																																									
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																																									
S	2006	Envoy	Body	Vehicle Theft Deterrent																																																									
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																							
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																																	
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																					
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																												
S	2006	Envoy XL	Body	Body Control Module																																																											
S	2006	Envoy XL	Body	Disc Player and Video Display																																																											
S	2006	Envoy XL	Body	Driver Door Module																																																											
S	2006	Envoy XL	Body	Driver Seat Module																								V																												V							
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																								V																												V	V					
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																								V																												V	V					
S	2006	Envoy XL	Body	Instrument Panel Cluster																V	V							V																																		
S	2006	Envoy XL	Body	Lift Gate Module																																																											
S	2006	Envoy XL	Body	Passenger Door Module																																																											
S	2006	Envoy XL	Body	Passenger Presence System																																																									V	
S	2006	Envoy XL	Body	Uplevel Radio																																																											
S	2006	Envoy XL	Body	Navigation Radio																																																											
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																								V																												V	V						
S	2006	Envoy XL	Body	Rear HVAC Manual																								V																												V	V						
S	2006	Envoy XL	Body	Rear Seat Audio																																																											
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																											
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																											
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																											
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																				V																																								
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																				V																																								
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																											
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																											
S	2007	Canyon	Body	Body Control Module																																																											
S	2007	Canyon	Body	Digital Radio Receiver																																																											
S	2007	Canyon	Body	Generator Battery Control Module																																																											
S	2007	Canyon	Body	Instrument Panel Cluster																																																											
S	2007	Canyon	Body	Passenger Presence System																																																									V	
S	2007	Canyon	Body	Base Radio																																																											
S	2007	Canyon	Body	Uplevel Radio																																																											
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																								
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																											
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																				V																																								
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																							
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																						
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																																							
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																						
S	2007	Envoy	Chassis	Electronic Brake Control Module																																																												
S	2007	Envoy	Body	Body Control Module																																																											
S	2007	Envoy	Body	Digital Radio Receiver																																																											
S	2007	Envoy	Body	Disc Player and Video Display																																																											
S	2007	Envoy	Body	Driver Door Module																																																											

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2007	Envoy	Body	Driver Seat Module																								V																															
S	2007	Envoy	Body	Generator Battery Control Module																																																							
S	2007	Envoy	Body	HVAC Control Module Auto																								V																															
S	2007	Envoy	Body	HVAC Control Module Manual																								V																															
S	2007	Envoy	Body	Instrument Panel Cluster																V	V							V																															
S	2007	Envoy	Body	Lift Gate Module																																																						
S	2007	Envoy	Body	Passenger Door Module																																																						
S	2007	Envoy	Body	Passenger Presence System																																																					V	
S	2007	Envoy	Body	Uplevel Radio																																																						
S	2007	Envoy	Body	Navigation Radio																																																						
S	2007	Envoy	Body	Rear Seat Audio																																																						
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																																						
S	2007	Envoy	Body	Theft Deterrent Module																																																						
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																																						
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																						
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																				V	V	V																																	
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																						
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																				V	V	V																																	
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																						
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																						
S	2008	Canyon	Body	Body Control Module																																																						
S	2008	Canyon	Body	Digital Radio Receiver																																																						
S	2008	Canyon	Body	Generator Battery Control Module																																																						
S	2008	Canyon	Body	Instrument Panel Cluster																																																						
S	2008	Canyon	Body	Passenger Presence System																																																				V	
S	2008	Canyon	Body	Base Radio																																																						
S	2008	Canyon	Body	Uplevel Radio																																																						
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																																						
S	2008	Canyon	Body	Theft Deterrent Module																																																						
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																																						
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																						
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V	V	V																																	
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																	
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																	
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																						
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																	
S	2008	Envoy	Chassis	Electronic Brake Control Module																																																						
S	2008	Envoy	Body	Body Control Module																																																						
S	2008	Envoy	Body	Digital Radio Receiver																																																						
S	2008	Envoy	Body	Disc Player and Video Display																																																						
S	2008	Envoy	Body	Driver Door Module																																																						
S	2008	Envoy	Body	Driver Seat Module																								V																															
S	2008	Envoy	Body	Generator Battery Control Module																																																						
S	2008	Envoy	Body	HVAC Control Module Auto																								V																															
S	2008	Envoy	Body	HVAC Control Module Manual																								V																															
S	2008	Envoy	Body	Instrument Panel Cluster																V	V							V																															
S	2008	Envoy	Body	Lift Gate Module																																																						
S	2008	Envoy	Body	Passenger Door Module																																																						
S	2008	Envoy	Body	Passenger Presence System																																																				V	
S	2008	Envoy	Body	Uplevel Radio																																																						
S	2008	Envoy	Body	Navigation Radio																																																						

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2008	Envoy	Body	Rear Seat Audio																																																								
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																																								
S	2008	Envoy	Body	Theft Deterrent Module																																																								
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																																								
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																								
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																								
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																								
S	2009	Canyon	Chassis	Electronic Brake Control Module																																																								
S	2009	Canyon	Body	Body Control Module																																																								
S	2009	Canyon	Body	Digital Radio Receiver																																																								
S	2009	Canyon	Body	Generator Battery Control Module																																																								
S	2009	Canyon	Body	Instrument Panel Cluster																																																								
S	2009	Canyon	Body	Passenger Presence System																																																								V
S	2009	Canyon	Body	Base Radio																																																								
S	2009	Canyon	Body	Uplevel Radio																																																								
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																																								
S	2009	Canyon	Body	Theft Deterrent Module																																																								
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																								
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																			
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																								
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																								
S	2009	Envoy	Chassis	Electronic Brake Control Module																																																								
S	2009	Envoy	Body	Body Control Module																																																								
S	2009	Envoy	Body	Digital Radio Receiver																																																								
S	2009	Envoy	Body	Disc Player and Video Display																																																								
S	2009	Envoy	Body	Driver Door Module																																																								
S	2009	Envoy	Body	Driver Seat Module																								V																										V						
S	2009	Envoy	Body	Generator Battery Control Module																																																								
S	2009	Envoy	Body	HVAC Control Module Auto																								V																											V					
S	2009	Envoy	Body	HVAC Control Module Manual																								V																											V					
S	2009	Envoy	Body	Instrument Panel Cluster																V	V							V																																
S	2009	Envoy	Body	Lift Gate Module																																																								
S	2009	Envoy	Body	Passenger Door Module																																																								
S	2009	Envoy	Body	Passenger Presence System																																																								V
S	2009	Envoy	Body	Uplevel Radio																																																								
S	2009	Envoy	Body	Navigation Radio																																																								
S	2009	Envoy	Body	Rear Seat Audio																																																								
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																																								
S	2009	Envoy	Body	Theft Deterrent Module																																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																									
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
S	2010	ALL	Chassis	Electronic Brake Control Module																																																									
S	2010	ALL	Body	Body Control Module																																																								
S	2010	ALL	Body	Digital Radio Receiver																																																								
S	2010	ALL	Body	Generator Battery Control Module																																																								
S	2010	ALL	Body	Instument Panel Cluster																																																								
S	2010	ALL	Body	Passenger Presence System																																																							V	
S	2010	ALL	Body	Personal Audio Link Module																									V																															
S	2010	ALL	Body	Base Radio																																																								
S	2010	ALL	Body	Uplevel Radio																																																								
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
S	2010	ALL	Body	Theft Deterrent Module																																																								
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																								
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																								
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																				
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																								
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																								
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																								
T	2004	Sonoma	Body	Body Control Module																																																								
T	2004	Sonoma	Body	Instrument Panel Cluster																																																								
T	2004	Sonoma	Body	Base Radio																																																								
T	2004	Sonoma	Body	Uplevel Radio																																																								
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																								
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																								
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																				V																																				
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																								
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																				V																																				
T	2004	Canyon	Chassis	ABS Without Traction Control																																																								
T	2004	Canyon	Chassis	ABS With Traction Control																																																								
T	2004	Canyon	Body	Body Control Module																																																								
T	2004	Canyon	Body	Instrument Panel Cluster																																																								
T	2004	Canyon	Body	OnStar																																																								
T	2004	Canyon	Body	Base Radio																																																								
T	2004	Canyon	Body	Uplevel Radio																																																								
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																																								
T	2004	Canyon	Body	Instrument Panel Cluster																																																								
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																				
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																								
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																								
T	2004	Envoy	Chassis	ABS Without Traction Control																																																								
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																								
T	2004	Envoy	Body	Amplifier (Bose)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2004	Envoy	Body	Body Control Module																																																										
T	2004	Envoy	Body	Driver Door Module																																																										
T	2004	Envoy	Body	Driver Seat Module																								V																												V						
T	2004	Envoy	Body	Heating and Air Conditioning Auto																								V																													V	V				
T	2004	Envoy	Body	Heating and Air Conditioning Manual																								V																													V	V				
T	2004	Envoy	Body	Instrument Panel Cluster																V	V							V																																		
T	2004	Envoy	Body	Lift Gate Module																																																										
T	2004	Envoy	Body	OnStar																																																										
T	2004	Envoy	Body	Passenger Door Module																																																										
T	2004	Envoy	Body	Uplevel Radio																																																										
T	2004	Envoy	Body	Navigation Radio																																																										
T	2004	Envoy	Body	Rear Seat Audio																																																										
T	2004	Envoy	Body	Rear Seat Entertainment																																																										
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy	Body	Vehicle Theft Deterrent																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																						
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																				V																																						
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy XL	Body	Amplifier (Bose)																																																										
T	2004	Envoy XL	Body	Body Control Module																																																										
T	2004	Envoy XL	Body	Driver Door Module																																																										
T	2004	Envoy XL	Body	Driver Seat Module																								V																												V						
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																								V																													V	V				
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																								V																													V	V				
T	2004	Envoy XL	Body	Instrument Panel Cluster																V	V							V																																		
T	2004	Envoy XL	Body	Lift Gate Module																																																										
T	2004	Envoy XL	Body	OnStar																																																										
T	2004	Envoy XL	Body	Passenger Door Module																																																										
T	2004	Envoy XL	Body	Uplevel Radio																																																										
T	2004	Envoy XL	Body	Navigation Radio																																																										
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																								V																													V	V				
T	2004	Envoy XL	Body	Rear HVAC Manual																								V																													V	V				
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																										
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																						
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																										
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																				V																																						
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																										
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																										
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2004	Envoy XUV	Body	Body Control Module																																																										
T	2004	Envoy XUV	Body	Driver Door Module																																																										
T	2004	Envoy XUV	Body	Driver Seat Module																								V																												V						
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																								V																													V	V				
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																								V																													V	V				
T	2004	Envoy XUV	Body	Instrument Panel Cluster																V	V							V																																		
T	2004	Envoy XUV	Body	Lift Gate Module																																																										
T	2004	Envoy XUV	Body	OnStar																																																										
T	2004	Envoy XUV	Body	Passenger Door Module																																																										
T	2004	Envoy XUV	Body	Uplevel Radio																																																										
T	2004	Envoy XUV	Body	Navigation Radio																																																										
T	2004	Envoy XUV	Body	Rear Seat Audio																																																										
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																										
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																										
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																										
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																						
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																										
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																										
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																										
T	2004	Jimmy	Body	Body Control Module																																																										
T	2004	Jimmy	Body	Heating and Air Conditioning																																																										
T	2004	Jimmy	Body	Instrument Panel Cluster																																																										
T	2004	Jimmy	Body	Memory Seat Module																																																										
T	2004	Jimmy	Body	Base Radio																																																										
T	2004	Jimmy	Body	Uplevel Radio																																																										
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																										
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																				V																																						
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																				V																																						
T	2005	Canyon	Chassis	ABS Without Traction Control																																																										
T	2005	Canyon	Chassis	ABS With Traction Control																																																										
T	2005	Canyon	Body	Body Control Module																																																										
T	2005	Canyon	Body	Instrument Panel Cluster																																																										
T	2005	Canyon	Body	Base Radio																																																										
T	2005	Canyon	Body	Uplevel Radio																																																										
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																																										
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																						
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																										
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																										
T	2005	Envoy	Chassis	ABS Without Traction Control																																																										
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																										
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																										
T	2005	Envoy	Body	Body Control Module																																																										
T	2005	Envoy	Body	Disc Player and Video Display																																																										
T	2005	Envoy	Body	Driver Door Module																																																										
T	2005	Envoy	Body	Driver Seat Module																									V																												V						
T	2005	Envoy	Body	Heating and Air Conditioning Auto																									V																													V	V				

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2005	Envoy	Body	Heating and Air Conditioning Manual																								V																												V	V				
T	2005	Envoy	Body	Instrument Panel Cluster																V	V							V																																
T	2005	Envoy	Body	Lift Gate Module																																																								
T	2005	Envoy	Body	Passenger Door Module																																																								
T	2005	Envoy	Body	Passenger Presence System																																																							V	
T	2005	Envoy	Body	Uplevel Radio																																																								
T	2005	Envoy	Body	Navigation Radio																																																								
T	2005	Envoy	Body	Rear Seat Audio																																																								
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																																								
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																																								
T	2005	Envoy	Body	Vehicle Theft Deterrent																																																								
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																				
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																														
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																		
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																								
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																								
T	2005	Envoy XL	Body	Body Control Module																																																								
T	2005	Envoy XL	Body	Disc Player and Video Display																																																								
T	2005	Envoy XL	Body	Driver Door Module																																																								
T	2005	Envoy XL	Body	Driver Seat Module																								V																										V						
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																								V																											V	V				
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																								V																											V	V				
T	2005	Envoy XL	Body	Instrument Panel Cluster																V	V							V																																
T	2005	Envoy XL	Body	Lift Gate Module																																																								
T	2005	Envoy XL	Body	Passenger Door Module																																																								
T	2005	Envoy XL	Body	Passenger Presence System																																																							V	
T	2005	Envoy XL	Body	Uplevel Radio																																																								
T	2005	Envoy XL	Body	Navigation Radio																																																								
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																								V																											V	V				
T	2005	Envoy XL	Body	Rear HVAC Manual																								V																											V	V				
T	2005	Envoy XL	Body	Rear Seat Audio																																																								
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																								
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																								
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																								
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																				
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																								
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																														
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																		
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																								
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																								
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																								
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																								
T	2005	Envoy XUV	Body	Body Control Module																																																								
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																								
T	2005	Envoy XUV	Body	Driver Door Module																																																								
T	2005	Envoy XUV	Body	Driver Seat Module																								V																																	

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																								V																											V	V				
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																								V																											V	V				
T	2005	Envoy XUV	Body	Instrument Panel Cluster																V	V							V																																
T	2005	Envoy XUV	Body	Lift Gate Module																																																									
T	2005	Envoy XUV	Body	Passenger Door Module																																																									
T	2005	Envoy XUV	Body	Passenger Presence System																																																								V	
T	2005	Envoy XUV	Body	Uplevel Radio																																																									
T	2005	Envoy XUV	Body	Navigation Radio																																																									
T	2005	Envoy XUV	Body	Rear Seat Audio																																																									
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																									
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																									
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																									
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																					
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																									
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																									
T	2005	Jimmy	Body	Body Control Module																																																									
T	2005	Jimmy	Body	Heating and Air Conditioning																																																									
T	2005	Jimmy	Body	Instrument Panel Cluster																																																									
T	2005	Jimmy	Body	Memory Seat Module																																																									
T	2005	Jimmy	Body	Base Radio																																																									
T	2005	Jimmy	Body	Uplevel Radio																																																									
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																									
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																				V																																					
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																									
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																									
T	2005	Sonoma	Body	Body Control Module																																																									
T	2005	Sonoma	Body	Instrument Panel Cluster																																																									
T	2005	Sonoma	Body	Base Radio																																																									
T	2005	Sonoma	Body	Uplevel Radio																																																									
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																									
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																				V																																					
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																				V																																					
T	2006	Canyon	Chassis	ABS Without Traction Control																																																									
T	2006	Canyon	Chassis	ABS With Traction Control																																																									
T	2006	Canyon	Body	Body Control Module																																																									
T	2006	Canyon	Body	Instrument Panel Cluster																																																									
T	2006	Canyon	Body	Passenger Presence System																																																								V	
T	2006	Canyon	Body	Base Radio																																																									
T	2006	Canyon	Body	Uplevel Radio																																																									
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																																									
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																																									
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																					
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																									
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																															

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																			
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																									
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module										V																																															
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																			
T	2006	Envoy	Chassis	ABS/TCS/VSES																																																										
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																										
T	2006	Envoy	Body	Body Control Module																																																										
T	2006	Envoy	Body	Disc Player and Video Display																																																										
T	2006	Envoy	Body	Driver Door Module																																																										
T	2006	Envoy	Body	Driver Seat Module																								V																																			
T	2006	Envoy	Body	Heating and Air Conditioning Auto																								V																																		
T	2006	Envoy	Body	Heating and Air Conditioning Manual																								V																																		
T	2006	Envoy	Body	Instrument Panel Cluster																V	V							V																																		
T	2006	Envoy	Body	Lift Gate Module																																																									
T	2006	Envoy	Body	Passenger Door Module																																																									
T	2006	Envoy	Body	Passenger Presence System																																																									V
T	2006	Envoy	Body	Uplevel Radio																																																									
T	2006	Envoy	Body	Navigation Radio																																																									
T	2006	Envoy	Body	Rear Seat Audio																																																									
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																																									
T	2006	Envoy	Body	Vehicle Theft Deterrent																																																									
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																																									
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																					
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																									
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module										V																																															
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																			
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																									
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																										
T	2006	Envoy XL	Body	Body Control Module																																																										
T	2006	Envoy XL	Body	Disc Player and Video Display																																																										
T	2006	Envoy XL	Body	Driver Door Module																																																										
T	2006	Envoy XL	Body	Driver Seat Module																								V																																			
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																								V																																		
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																								V																																		
T	2006	Envoy XL	Body	Instrument Panel Cluster																V	V							V																																		
T	2006	Envoy XL	Body	Lift Gate Module																																																									
T	2006	Envoy XL	Body	Passenger Door Module																																																									
T	2006	Envoy XL	Body	Passenger Presence System																																																									V
T	2006	Envoy XL	Body	Uplevel Radio																																																									
T	2006	Envoy XL	Body	Navigation Radio																																																									
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																								V																																		
T	2006	Envoy XL	Body	Rear HVAC Manual																								V																																		
T	2006	Envoy XL	Body	Rear Seat Audio																																																									
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																									
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																									
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																									
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																				V																																					
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																									
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																				V																																				
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																								
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																								
T	2007	Canyon	Body	Body Control Module																																																								
T	2007	Canyon	Body	Digital Radio Receiver																																																								
T	2007	Canyon	Body	Generator Battery Control Module																																																								
T	2007	Canyon	Body	Instrument Panel Cluster																																																								
T	2007	Canyon	Body	Passenger Presence System																																																								
T	2007	Canyon	Body	Base Radio																																																								
T	2007	Canyon	Body	Uplevel Radio																																																								
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																																								
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																																								
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V																																				
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																								
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																								
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																				V																																				
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																								
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																			
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																		
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module					V																																																			
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																		
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																								
T	2007	Envoy	Chassis	Electronic Brake Control Module																																																								
T	2007	Envoy	Body	Body Control Module																																																								
T	2007	Envoy	Body	Digital Radio Receiver																																																								
T	2007	Envoy	Body	Disc Player and Video Display																																																								
T	2007	Envoy	Body	Driver Door Module																																																								
T	2007	Envoy	Body	Driver Seat Module																								V																																
T	2007	Envoy	Body	Generator Battery Control Module																																																								
T	2007	Envoy	Body	HVAC Control Module Auto																								V																																
T	2007	Envoy	Body	HVAC Control Module Manual																								V																																
T	2007	Envoy	Body	Instrument Panel Cluster																V	V							V																																
T	2007	Envoy	Body	Lift Gate Module																																																								
T	2007	Envoy	Body	Passenger Door Module																																																								
T	2007	Envoy	Body	Passenger Presence System																																																								
T	2007	Envoy	Body	Uplevel Radio																																																								
T	2007	Envoy	Body	Navigation Radio																																																								
T	2007	Envoy	Body	Rear Seat Audio																																																								
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																																								
T	2007	Envoy	Body	Theft Deterrent Module																																																								
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																																								
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																				V	V	V																																		
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																				V	V	V																																		
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2008	Canyon	Body	Body Control Module																																																								
T	2008	Canyon	Body	Digital Radio Receiver																																																								
T	2008	Canyon	Body	Generator Battery Control Module																																																								
T	2008	Canyon	Body	Instrument Panel Cluster																																																								
T	2008	Canyon	Body	Passenger Presence System																																																								
T	2008	Canyon	Body	Base Radio																																																								
T	2008	Canyon	Body	Uplevel Radio																																																								
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																																								
T	2008	Canyon	Body	Theft Deterrent Module																																																								
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																																								
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																				V	V	V																																		
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																								
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																			
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																				V	V	V																																		
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																								
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																				V	V	V																																		
T	2008	Envoy	Chassis	Electronic Brake Control Module																																																								
T	2008	Envoy	Body	Body Control Module																																																								
T	2008	Envoy	Body	Digital Radio Receiver																																																								
T	2008	Envoy	Body	Disc Player and Video Display																																																								
T	2008	Envoy	Body	Driver Door Module																																																								
T	2008	Envoy	Body	Driver Seat Module																								V																											V					
T	2008	Envoy	Body	Generator Battery Control Module																																																								
T	2008	Envoy	Body	HVAC Control Module Auto																								V																												V				
T	2008	Envoy	Body	HVAC Control Module Manual																								V																												V				
T	2008	Envoy	Body	Instrument Panel Cluster																V	V							V																																
T	2008	Envoy	Body	Lift Gate Module																																																								
T	2008	Envoy	Body	Passenger Door Module																																																								
T	2008	Envoy	Body	Passenger Presence System																																																								
T	2008	Envoy	Body	Uplevel Radio																																																								
T	2008	Envoy	Body	Navigation Radio																																																								
T	2008	Envoy	Body	Rear Seat Audio																																																								
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																																								
T	2008	Envoy	Body	Theft Deterrent Module																																																								
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																																								
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																								
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																								
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																								
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																								
T	2009	Canyon	Chassis	Electronic Brake Control Module																																																								
T	2009	Canyon	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2009	Canyon	Body	Digital Radio Receiver																																																									
T	2009	Canyon	Body	Generator Battery Control Module																																																									
T	2009	Canyon	Body	Instrument Panel Cluster																																																									
T	2009	Canyon	Body	Passenger Presence System																																																									
T	2009	Canyon	Body	Base Radio																																																									
T	2009	Canyon	Body	Uplevel Radio																																																									
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																																									
T	2009	Canyon	Body	Theft Deterrent Module																																																									
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																									
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module					V																																																				
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																									
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																									
T	2009	Envoy	Body	Body Control Module																																																									
T	2009	Envoy	Body	Digital Radio Receiver																																																									
T	2009	Envoy	Body	Disc Player and Video Display																																																									
T	2009	Envoy	Body	Driver Door Module																																																									
T	2009	Envoy	Body	Driver Seat Module																								V																										V							
T	2009	Envoy	Body	Generator Battery Control Module																																																									
T	2009	Envoy	Body	HVAC Control Module Auto																								V																											V						
T	2009	Envoy	Body	HVAC Control Module Manual																								V																											V						
T	2009	Envoy	Body	Instrument Panel Cluster																V	V							V																																	
T	2009	Envoy	Body	Lift Gate Module																																																									
T	2009	Envoy	Body	Passenger Door Module																																																									
T	2009	Envoy	Body	Passenger Presence System																																																									
T	2009	Envoy	Body	Uplevel Radio																																																									
T	2009	Envoy	Body	Navigation Radio																																																									
T	2009	Envoy	Body	Rear Seat Audio																																																									
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																																									
T	2009	Envoy	Body	Theft Deterrent Module																																																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																									
T	2010	ALL	Chassis	Electronic Brake Control Module																																																									
T	2010	ALL	Body	Body Control Module																																																									
T	2010	ALL	Body	Digital Radio Receiver																																																									
T	2010	ALL	Body	Generator Battery Control Module																																																									
T	2010	ALL	Body	Instrument Panel Cluster																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
T	2010	ALL	Body	Passenger Presence System																																																								
T	2010	ALL	Body	Personal Audio Link Module																										V																															
T	2010	ALL	Body	Base Radio																																																								
T	2010	ALL	Body	Uplevel Radio																																																								
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																								
T	2010	ALL	Body	Theft Deterrent Module																																																								
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																								
V	2007	ALL	Powertrain	Engine Control Module																																																								
V	2007	ALL	Powertrain	Rear Drive System																																																								
V	2007	ALL	Powertrain	Transmission Control Module																																																								
V	2007	ALL	Chassis	Electronic Brake Control Module																																																								
V	2007	ALL	Body	Body Control Module																																																								
V	2007	ALL	Body	Digital Radio Receiver																																																								
V	2007	ALL	Body	Driver Door Switch																																																								
V	2007	ALL	Body	Head Up Display																																																								
V	2007	ALL	Body	Heated Seat Module																																																								
V	2007	ALL	Body	HVAC Control Module Auto																																																								
V	2007	ALL	Body	HVAC Control Module Manual																																																								
V	2007	ALL	Body	Instrument Panel Cluster																																																								
V	2007	ALL	Body	Lift Gate Module																																																								
V	2007	ALL	Body	Park Assist Module																																																								
V	2007	ALL	Body	Passenger Door Switch																																																								
V	2007	ALL	Body	Passenger Presence System																																																								
V	2007	ALL	Body	Radio																																																								
V	2007	ALL	Body	Rear HVAC/RSA																																																								
V	2007	ALL	Body	Rollover Sensor																																																								
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2007	ALL	Body	Theft Deterrent Module																																																								
V	2008	ALL	Powertrain	Engine Control Module																																																								
V	2008	ALL	Powertrain	Rear Drive System																																																								
V	2008	ALL	Powertrain	Transmission Control Module																																																								
V	2008	ALL	Chassis	Electronic Brake Control Module																																																								
V	2008	ALL	Body	Body Control Module																																																								
V	2008	ALL	Body	Digital Radio Receiver																																																								
V	2008	ALL	Body	Driver Door Switch																																																								
V	2008	ALL	Body	Head Up Display																																																								
V	2008	ALL	Body	Heated Seat Module																																																								
V	2008	ALL	Body	HVAC Control Module Auto																																																								
V	2008	ALL	Body	HVAC Control Module Manual																																																								
V	2008	ALL	Body	Instrument Panel Cluster																																																								
V	2008	ALL	Body	Lift Gate Module																																																								
V	2008	ALL	Body	Park Assist Module																																																								
V	2008	ALL	Body	Passenger Door Switch																																																								
V	2008	ALL	Body	Passenger Presence System																																																								
V	2008	ALL	Body	Radio																																																								
V	2008	ALL	Body	Rear HVAC/RSA																																																								
V	2008	ALL	Body	Rollover Sensor																																																								
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																								
V	2008	ALL	Body	Theft Deterrent Module																																																								
V	2009	ALL	Powertrain	Engine Control Module																																																								
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
V	2009	ALL	Powertrain	Rear Drive System																																																									
V	2009	ALL	Powertrain	Transmission Control Module																																																									
V	2009	ALL	Chassis	Electronic Brake Control Module																																																									
V	2009	ALL	Body	Body Control Module																																																									
V	2009	ALL	Body	Digital Radio Receiver																																																									
V	2009	ALL	Body	Driver Door Switch																																																									
V	2009	ALL	Body	Head Up Display																																																									
V	2009	ALL	Body	Heated Seat Module																																																									
V	2009	ALL	Body	HVAC Control Module Auto																																																									
V	2009	ALL	Body	HVAC Control Module Manual																																																									
V	2009	ALL	Body	Instrument Panel Cluster																																																									
V	2009	ALL	Body	Lift Gate Module																																																									
V	2009	ALL	Body	Park Assist Module																																																									
V	2009	ALL	Body	Passenger Door Switch																																																									
V	2009	ALL	Body	Passenger Presence System																																																									
V	2009	ALL	Body	Radio																																																									
V	2009	ALL	Body	Rear HVAC/RSA																																																									
V	2009	ALL	Body	Rollover Sensor																																																									
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2009	ALL	Body	Theft Deterrent Module																																																									
V	2010	ALL	Powertrain	Engine Control Module																																																									
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2010	ALL	Powertrain	Rear Drive System																																																									
V	2010	ALL	Powertrain	Transmission Control Module																																																									
V	2010	ALL	Chassis	Electronic Brake Control Module																																																									
V	2010	ALL	Body	Body Control Module																																																									
V	2010	ALL	Body	Digital Radio Receiver																																																									
V	2010	ALL	Body	Driver Door Switch																																																									
V	2010	ALL	Body	Head Up Display																																																									
V	2010	ALL	Body	Heated Seat Module																																																									
V	2010	ALL	Body	HVAC Control Module Auto									V																																																
V	2010	ALL	Body	HVAC Control Module Manual																																																									
V	2010	ALL	Body	Instrument Panel Cluster																																																									
V	2010	ALL	Body	Lift Gate Module																																																									
V	2010	ALL	Body	Park Assist Module																																																									
V	2010	ALL	Body	Passenger Door Switch																																																									
V	2010	ALL	Body	Passenger Presence System																																																									
V	2010	ALL	Body	Radio																																																									
V	2010	ALL	Body	Rear HVAC/RSA																																																									
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2010	ALL	Body	Theft Deterrent Module																																																									
V	2011	ALL	Powertrain	Engine Control Module																																																									
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																									
V	2011	ALL	Powertrain	Rear Drive System																																																									
V	2011	ALL	Powertrain	Transmission Control Module																																																									
V	2011	ALL	Chassis	Electronic Brake Control Module																																																									
V	2011	ALL	Body	Body Control Module																																																									
V	2011	ALL	Body	Digital Radio Receiver																																																									
V	2011	ALL	Body	Driver Door Switch																																																									
V	2011	ALL	Body	Head Up Display																																																									
V	2011	ALL	Body	Heated Seat Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
V	2011	ALL	Body	HVAC Control Module Auto									V																																																	
V	2011	ALL	Body	HVAC Control Module Manual																																																											
V	2011	ALL	Body	Instrument Panel Cluster																																																											
V	2011	ALL	Body	Lift Gate Module																																																											
V	2011	ALL	Body	Park Assist Module																																																											
V	2011	ALL	Body	Passenger Door Switch																																																											
V	2011	ALL	Body	Passenger Presence System																																																											
V	2011	ALL	Body	Radio																																																											
V	2011	ALL	Body	Rear HVAC/RSA																																																											
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2011	ALL	Body	Theft Deterrent Module																																																											
V	2012	ALL	Powertrain	Engine Control Module																																																											
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2012	ALL	Powertrain	Rear Drive System																																																											
V	2012	ALL	Powertrain	Transmission Control Module																																																											
V	2012	ALL	Chassis	Electronic Brake Control Module																																																											
V	2012	ALL	Body	Body Control Module																																																											
V	2012	ALL	Body	Digital Radio Receiver																																																											
V	2012	ALL	Body	Driver Door Switch																																																											
V	2012	ALL	Body	Head Up Display																																																											
V	2012	ALL	Body	Heated Seat Module																																																											
V	2012	ALL	Body	HVAC Control Module Auto									V																																																		
V	2012	ALL	Body	HVAC Control Module Manual																																																												
V	2012	ALL	Body	Instrument Panel Cluster																																																											
V	2012	ALL	Body	Lift Gate Module																																																											
V	2012	ALL	Body	Park Assist Module																																																											
V	2012	ALL	Body	Passenger Door Switch																																																											
V	2012	ALL	Body	Passenger Presence System																																																											
V	2012	ALL	Body	Radio																																																											
V	2012	ALL	Body	Rear HVAC/RSA																																																											
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
V	2012	ALL	Body	Theft Deterrent Module																																																											
V	2013	ALL	Powertrain	Engine Control Module																																																											
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																											
V	2013	ALL	Powertrain	Rear Drive System																																																											
V	2013	ALL	Powertrain	Transmission Control Module																																																											
V	2013	ALL	Chassis	Electronic Brake Control Module																																																											
V	2013	ALL	Body	Body Control Module																																																											
V	2013	ALL	Body	Digital Radio Receiver																																																											
V	2013	ALL	Body	Driver Door Switch																																																											
V	2013	ALL	Body	Head Up Display																																																											
V	2013	ALL	Body	Heated Seat Module																																																											
V	2013	ALL	Body	HVAC Control Module Auto									V																																																		
V	2013	ALL	Body	HVAC Control Module Manual																																																												
V	2013	ALL	Body	Instrument Panel Cluster																																																											
V	2013	ALL	Body	Left Side Object Detection Module																																																											
V	2013	ALL	Body	Lift Gate Module																																																											
V	2013	ALL	Body	Park Assist Module																																																											
V	2013	ALL	Body	Passenger Door Switch																																																											
V	2013	ALL	Body	Passenger Presence System																																																											
V	2013	ALL	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
V	2013	ALL	Body	Rear HVAC/RSA																																																									
V	2013	ALL	Body	Right Side Object Detection Module																																																									
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																									
V	2013	ALL	Body	Theft Deterrent Module																																																									
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2014	Acadia	Powertrain	Chassis Control Module																																																									
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																									
V	2014	Acadia	Chassis	Electronic Brake Control Module																																												V													
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																									
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2014	Acadia	Body	Passenger Presence Module																																																									
V	2014	Acadia	Body	Instrument Cluster																																																									
V	2014	Acadia	Body	Head-Up Display Module																																																									
V	2014	Acadia	Body	Radio																																																									
V	2014	Acadia	Body	Rear Audio Control Module																																																									
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																									
V	2014	Acadia	Body	Personal Audio Link Control Module																																														V											
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																									
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																									
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																									
V	2014	Acadia	Body	Liftgate Control Module																																																									
V	2014	Acadia	Body	Seat Memory Control Module																																																									
V	2014	Acadia	Body	Front Seat Heating Control Module																																																									
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																									
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																									
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																									
V	2014	Acadia	Body	Parking Assist Control Module																																																									
V	2014	Acadia	Body	Frontview Camera Module																																																									
V	2014	Acadia	Body	Theft Deterrent Module																																																									
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																									
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																									
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																									
V	2015	Acadia	Chassis	Electronic Brake Control Module																																												V											
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																									
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																									
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
V	2015	Acadia	Body	Passenger Presence Module																																																									
V	2015	Acadia	Body	Instrument Cluster																																																									
V	2015	Acadia	Body	Head-Up Display Module																																																									
V	2015	Acadia	Body	Radio																																																									
V	2015	Acadia	Body	Rear Audio Control Module																																																									
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																									
V	2015	Acadia	Body	Personal Audio Link Control Module																																													V											
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																									
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																									
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																									
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																										
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
V	2015	Acadia	Body	Liftgate Control Module																																																										
V	2015	Acadia	Body	Seat Memory Control Module																																																										
V	2015	Acadia	Body	Front Seat Heating Control Module																																																										
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																										
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																										
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																										
V	2015	Acadia	Body	Parking Assist Control Module																																																										
V	2015	Acadia	Body	Frontview Camera Module																																																										
V	2015	Acadia	Body	Theft Deterrent Module																																																										
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																										
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																										
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																										
V	2016	Acadia	Chassis	Electronic Brake Control Module																																												V													
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																										
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																										
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
V	2016	Acadia	Body	Passenger Presence Module																																																										
V	2016	Acadia	Body	Instrument Cluster																																																										
V	2016	Acadia	Body	Head-Up Display Module																																																										
V	2016	Acadia	Body	Radio																																																										
V	2016	Acadia	Body	Rear Audio Control Module																																																										
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																										
V	2016	Acadia	Body	Personal Audio Link Control Module																																															V											
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																										
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																										
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																										
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																										
V	2016	Acadia	Body	Liftgate Control Module																																																										
V	2016	Acadia	Body	Seat Memory Control Module																																																										
V	2016	Acadia	Body	Front Seat Heating Control Module																																																										
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																										
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																										
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																										
V	2016	Acadia	Body	Parking Assist Control Module																																																										
V	2016	Acadia	Body	Frontview Camera Module																																																										
V	2016	Acadia	Body	Theft Deterrent Module																																																										
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																			
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																									
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module											V																																													
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																									
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																									
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																									
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																									
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																									
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
1	2011	Sierra	Chassis	Electronic Suspension Control																																																									
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																									
1	2011	Sierra	Body	Amplifier (Bose)																																																									
1	2011	Sierra	Body	Body Control Module																																																									
1	2011	Sierra	Body	Body Control Module (aux.)																																																									
1	2011	Sierra	Body	Digital Radio Receiver																																																									
1	2011	Sierra	Body	Driver Door Switch																																																									
1	2011	Sierra	Body	HVAC Control Module Auto									V																																															
1	2011	Sierra	Body	HVAC Control Module Manual									V																																															
1	2011	Sierra	Body	Instrument Panel Cluster																																																									
1	2011	Sierra	Body	Memory Seat Module																																																									
1	2011	Sierra	Body	Park Assist Module																																																									
1	2011	Sierra	Body	Passenger Door Switch																																																									
1	2011	Sierra	Body	Passenger Presence System																																																									
1	2011	Sierra	Body	Radio																																																								
1	2011	Sierra	Body	Rear Heated Seat Module																																																									
1	2011	Sierra	Body	Rear HVAC/RSA																																																									
1	2011	Sierra	Body	Supplemental Inflatable Restraint																																																									
1	2011	Sierra	Body	Theft Deterrent Module																																																									
1	2011	Sierra Hybrid	Powertrain	Engine Control Module					V																																																				
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																									
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																									
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																									
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																									
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																									
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																									
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																									
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																									
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																									
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																									
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																									
1	2011	Sierra Hybrid	Body	Body Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																								
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																								
1	2011	Sierra Hybrid	Body	Driver Door Switch																																																								
1	2011	Sierra Hybrid	Body	Heated Seat Module																																																								
1	2011	Sierra Hybrid	Body	HVAC Control Module																																																								
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																								
1	2011	Sierra Hybrid	Body	Park Assist Module																																																								
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																																								
1	2011	Sierra Hybrid	Body	Passenger Presence System																																																								
1	2011	Sierra Hybrid	Body	Radio																																																								
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																								
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																								
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																								
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																														
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
1	2011	Yukon	Chassis	Electronic Brake Control Module																																																								
1	2011	Yukon	Chassis	Electronic Suspension Control																																																								
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																								
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
1	2011	Yukon	Body	Amplifier (Bose)																																																								
1	2011	Yukon	Body	Assist Step Controller																																																								
1	2011	Yukon	Body	Body Control Module																																																								
1	2011	Yukon	Body	Body Control Module (aux.)																																																								
1	2011	Yukon	Body	Digital Radio Receiver																																																								
1	2011	Yukon	Body	Driver Door Switch																																																								
1	2011	Yukon	Body	HVAC Control Module Auto									V																																															
1	2011	Yukon	Body	HVAC Control Module Manual																																																								
1	2011	Yukon	Body	Instrument Panel Cluster																																																								
1	2011	Yukon	Body	Left Side Object Detection Module																																																								
1	2011	Yukon	Body	Lift Gate Module																																																								
1	2011	Yukon	Body	Memory Seat Module																																																								
1	2011	Yukon	Body	Park Assist Module																																																								
1	2011	Yukon	Body	Passenger Door Switch																																																								
1	2011	Yukon	Body	Passenger Presence System																																																								
1	2011	Yukon	Body	Radio																																																								
1	2011	Yukon	Body	Rear Heated Seat Module																																																								
1	2011	Yukon	Body	Rear HVAC/RSA																																																								
1	2011	Yukon	Body	Right Side Object Detection Module																																																								
1	2011	Yukon	Body	Supplemental Inflatable Restraint																																																								
1	2011	Yukon	Body	Theft Deterrent Module																																																								
1	2011	Yukon Hybrid	Powertrain	Engine Control Module					V																																																			
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2011	Yukon Hybrid	Body	Body Control Module																																																										
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																										
1	2011	Yukon Hybrid	Body	HVAC Control Module																																																										
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
1	2011	Yukon Hybrid	Body	Lift Gate Module																																																										
1	2011	Yukon Hybrid	Body	Park Assist Module																																																										
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2011	Yukon Hybrid	Body	Passenger Presence System																																																										
1	2011	Yukon Hybrid	Body	Radio																																																										
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																															
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																										
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon XL	Body	Amplifier (Bose)																																																										
1	2011	Yukon XL	Body	Assist Step Controller																																																										
1	2011	Yukon XL	Body	Body Control Module																																																										
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2011	Yukon XL	Body	Digital Radio Receiver																																																										
1	2011	Yukon XL	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2011	Yukon XL	Body	HVAC Control Module Auto									V																																																		
1	2011	Yukon XL	Body	HVAC Control Module Manual																																																												
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																												
1	2011	Yukon XL	Body	Left Side Object Detection Module																																																												
1	2011	Yukon XL	Body	Lift Gate Module																																																												
1	2011	Yukon XL	Body	Memory Seat Module																																																												
1	2011	Yukon XL	Body	Park Assist Module																																																												
1	2011	Yukon XL	Body	Passenger Door Switch																																																												
1	2011	Yukon XL	Body	Passenger Presence System																																																												
1	2011	Yukon XL	Body	Radio																																																												
1	2011	Yukon XL	Body	Rear Heated Seat Module																																																												
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																												
1	2011	Yukon XL	Body	Right Side Object Detection Module																																																												
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
1	2011	Yukon XL	Body	Theft Deterrent Module																																																												
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																						
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																																		
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																		
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																																	
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module											V																																																	
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
1	2012	Sierra	Chassis	Electronic Suspension Control																																																												
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																												
1	2012	Sierra	Body	Amplifier (Bose)																																																												
1	2012	Sierra	Body	Body Control Module																																																												
1	2012	Sierra	Body	Body Control Module (aux.)																																																												
1	2012	Sierra	Body	Digital Radio Receiver																																																												
1	2012	Sierra	Body	Driver Door Switch																																																												
1	2012	Sierra	Body	HVAC Control Module Auto									V																																																		

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2012	Sierra	Body	HVAC Control Module Manual									V																																																
1	2012	Sierra	Body	Instrument Panel Cluster																																																										
1	2012	Sierra	Body	Memory Seat Module																																																										
1	2012	Sierra	Body	Park Assist Module																																																										
1	2012	Sierra	Body	Passenger Door Switch																																																										
1	2012	Sierra	Body	Passenger Presence System																																																										
1	2012	Sierra	Body	Radio																																																										
1	2012	Sierra	Body	Navigation Radio																																																										
1	2012	Sierra	Body	Rear Heated Seat Module																																																										
1	2012	Sierra	Body	Rear HVAC/RSA																																																										
1	2012	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2012	Sierra	Body	Theft Deterrent Module																																																										
1	2012	Sierra Hybrid	Powertrain	Engine Control Module					V																																																					
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
1	2012	Sierra Hybrid	Body	Body Control Module																																																										
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2012	Sierra Hybrid	Body	Driver Door Switch																																																										
1	2012	Sierra Hybrid	Body	Heated Seat Module																																																										
1	2012	Sierra Hybrid	Body	HVAC Control Module																																																										
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2012	Sierra Hybrid	Body	Park Assist Module																																																										
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																																										
1	2012	Sierra Hybrid	Body	Passenger Presence System																																																										
1	2012	Sierra Hybrid	Body	Radio																																																										
1	2012	Sierra Hybrid	Body	Navigation Radio																																																										
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																																
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2012	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2012	Yukon	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																								
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
1	2012	Yukon	Body	Amplifier (Bose)																																																								
1	2012	Yukon	Body	Assist Step Controller																																																								
1	2012	Yukon	Body	Body Control Module																																																								
1	2012	Yukon	Body	Body Control Module (aux.)																																																								
1	2012	Yukon	Body	Digital Radio Receiver																																																								
1	2012	Yukon	Body	Driver Door Switch																																																								
1	2012	Yukon	Body	HVAC Control Module Auto									V																																															
1	2012	Yukon	Body	HVAC Control Module Manual																																																									
1	2012	Yukon	Body	Instrument Panel Cluster																																																								
1	2012	Yukon	Body	Left Side Object Detection Module																																																								
1	2012	Yukon	Body	Lift Gate Module																																																								
1	2012	Yukon	Body	Memory Seat Module																																																								
1	2012	Yukon	Body	Park Assist Module																																																								
1	2012	Yukon	Body	Passenger Door Switch																																																								
1	2012	Yukon	Body	Passenger Presence System																																																								
1	2012	Yukon	Body	Radio																																																								
1	2012	Yukon	Body	Navigation Radio																																																								
1	2012	Yukon	Body	Rear Heated Seat Module																																																								
1	2012	Yukon	Body	Rear HVAC/RSA																																																								
1	2012	Yukon	Body	Right Side Object Detection Module																																																								
1	2012	Yukon	Body	Supplemental Inflatable Restraint																																																								
1	2012	Yukon	Body	Theft Deterrent Module																																																								
1	2012	Yukon Hybrid	Powertrain	Engine Control Module					V																																																			
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																								
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																								
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																								
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																								
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																								
1	2012	Yukon Hybrid	Body	Body Control Module																																																								
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																								
1	2012	Yukon Hybrid	Body	Driver Door Switch																																																								
1	2012	Yukon Hybrid	Body	Heated Seat Module																																																								
1	2012	Yukon Hybrid	Body	HVAC Control Module																																																								
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
1	2012	Yukon Hybrid	Body	Lift Gate Module																																																								
1	2012	Yukon Hybrid	Body	Park Assist Module																																																								
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																																								
1	2012	Yukon Hybrid	Body	Passenger Presence System																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2012	Yukon Hybrid	Body	Radio																																																									
1	2012	Yukon Hybrid	Body	Navigation Radio																																																									
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																									
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																									
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																									
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																									
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																									
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																									
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																															
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																															
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																									
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																									
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																									
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
1	2012	Yukon XL	Body	Amplifier (Bose)																																																									
1	2012	Yukon XL	Body	Assist Step Controller																																																									
1	2012	Yukon XL	Body	Body Control Module																																																									
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																									
1	2012	Yukon XL	Body	Digital Radio Receiver																																																									
1	2012	Yukon XL	Body	Driver Door Switch																																																									
1	2012	Yukon XL	Body	HVAC Control Module Auto									V																																																
1	2012	Yukon XL	Body	HVAC Control Module Manual																																																									
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																									
1	2012	Yukon XL	Body	Left Side Object Detection Module																																																									
1	2012	Yukon XL	Body	Lift Gate Module																																																									
1	2012	Yukon XL	Body	Memory Seat Module																																																									
1	2012	Yukon XL	Body	Park Assist Module																																																									
1	2012	Yukon XL	Body	Passenger Door Switch																																																									
1	2012	Yukon XL	Body	Passenger Presence System																																																									
1	2012	Yukon XL	Body	Radio																																																									
1	2012	Yukon XL	Body	Navigation Radio																																																									
1	2012	Yukon XL	Body	Rear Heated Seat Module																																																									
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																									
1	2012	Yukon XL	Body	Right Side Object Detection Module																																																									
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
1	2012	Yukon XL	Body	Theft Deterrent Module																																																									
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																					V																				
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																									
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																															
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																									
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																									
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																									
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																									
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																									
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																									
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module											V																																														
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																									
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																									
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																									
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																									
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																									
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																									
1	2013	Sierra	Chassis	Electronic Suspension Control																																																									
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Sierra	Body	Amplifier (Bose)																																																									
1	2013	Sierra	Body	Body Control Module																																																									
1	2013	Sierra	Body	Body Control Module (aux.)																																																									
1	2013	Sierra	Body	Digital Radio Receiver																																																									
1	2013	Sierra	Body	Driver Door Switch																																																									
1	2013	Sierra	Body	HVAC Control Module Auto									V																																															
1	2013	Sierra	Body	HVAC Control Module Manual									V																																															
1	2013	Sierra	Body	Instrument Panel Cluster																																																									
1	2013	Sierra	Body	Memory Seat Module																																																									
1	2013	Sierra	Body	Park Assist Module																																																									
1	2013	Sierra	Body	Passenger Door Switch																																																									
1	2013	Sierra	Body	Passenger Presence System																																																									
1	2013	Sierra	Body	Radio																																																									
1	2013	Sierra	Body	Navigation Radio																																																									
1	2013	Sierra	Body	Rear Heated Seat Module																																																									
1	2013	Sierra	Body	Rear HVAC/RSA																																																									
1	2013	Sierra	Body	Supplemental Inflatable Restraint																																																									
1	2013	Sierra	Body	Theft Deterrent Module																																																									
1	2013	Sierra Hybrid	Powertrain	Engine Control Module					V																																																				
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																									
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																									
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																									
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																									
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																									
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																									
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																									
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																									
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																									
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																									
1	2013	Sierra Hybrid	Body	Body Control Module																																																									
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																									
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																									
1	2013	Sierra Hybrid	Body	Driver Door Switch																																																									
1	2013	Sierra Hybrid	Body	Heated Seat Module																																																									
1	2013	Sierra Hybrid	Body	HVAC Control Module																																																									
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																									
1	2013	Sierra Hybrid	Body	Park Assist Module																																																									
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																																									
1	2013	Sierra Hybrid	Body	Passenger Presence System																																																									
1	2013	Sierra Hybrid	Body	Radio																																																									
1	2013	Sierra Hybrid	Body	Navigation Radio																																																									
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																									
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																									
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																									
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																									
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																									
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																															
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																									
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2013	Yukon	Chassis	Electronic Brake Control Module																																																									
1	2013	Yukon	Chassis	Electronic Suspension Control																																																									
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Yukon	Body	Amplifier (Bose)																																																									
1	2013	Yukon	Body	Assist Step Controller																																																									
1	2013	Yukon	Body	Body Control Module																																																									
1	2013	Yukon	Body	Body Control Module (aux.)																																																									
1	2013	Yukon	Body	Digital Radio Receiver																																																									
1	2013	Yukon	Body	Driver Door Switch																																																									
1	2013	Yukon	Body	HVAC Control Module Auto									V																																															
1	2013	Yukon	Body	HVAC Control Module Manual																																																									
1	2013	Yukon	Body	Instrument Panel Cluster																																																									
1	2013	Yukon	Body	Left Side Object Detection Module																																																									
1	2013	Yukon	Body	Lift Gate Module																																																									
1	2013	Yukon	Body	Memory Seat Module																																																									
1	2013	Yukon	Body	Park Assist Module																																																									
1	2013	Yukon	Body	Passenger Door Switch																																																									
1	2013	Yukon	Body	Passenger Presence System																																																									
1	2013	Yukon	Body	Radio																																																									
1	2013	Yukon	Body	Navigation Radio																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2013	Yukon	Body	Rear Heated Seat Module																																																								
1	2013	Yukon	Body	Rear HVAC/RSA																																																								
1	2013	Yukon	Body	Right Side Object Detection Module																																																								
1	2013	Yukon	Body	Supplemental Inflatable Restraint																																																								
1	2013	Yukon	Body	Theft Deterrent Module																																																								
1	2013	Yukon Hybrid	Powertrain	Engine Control Module					V																																																			
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																								
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																								
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																								
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																								
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																								
1	2013	Yukon Hybrid	Body	Body Control Module																																																								
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																								
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																								
1	2013	Yukon Hybrid	Body	Driver Door Switch																																																								
1	2013	Yukon Hybrid	Body	Heated Seat Module																																																								
1	2013	Yukon Hybrid	Body	HVAC Control Module																																																								
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
1	2013	Yukon Hybrid	Body	Lift Gate Module																																																								
1	2013	Yukon Hybrid	Body	Park Assist Module																																																								
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																																								
1	2013	Yukon Hybrid	Body	Passenger Presence System																																																								
1	2013	Yukon Hybrid	Body	Radio																																																								
1	2013	Yukon Hybrid	Body	Navigation Radio																																																								
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																								
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																								
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																														
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																														
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																									
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																									
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																									
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																									
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																									
1	2013	Yukon XL	Body	Amplifier (Bose)																																																									
1	2013	Yukon XL	Body	Assist Step Controller																																																									
1	2013	Yukon XL	Body	Body Control Module																																																									
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																									
1	2013	Yukon XL	Body	Digital Radio Receiver																																																									
1	2013	Yukon XL	Body	Driver Door Switch																																																									
1	2013	Yukon XL	Body	HVAC Control Module Auto									V																																																
1	2013	Yukon XL	Body	HVAC Control Module Manual																																																									
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																									
1	2013	Yukon XL	Body	Left Side Object Detection Module																																																									
1	2013	Yukon XL	Body	Lift Gate Module																																																									
1	2013	Yukon XL	Body	Memory Seat Module																																																									
1	2013	Yukon XL	Body	Park Assist Module																																																									
1	2013	Yukon XL	Body	Passenger Door Switch																																																									
1	2013	Yukon XL	Body	Passenger Presence System																																																									
1	2013	Yukon XL	Body	Radio																																																									
1	2013	Yukon XL	Body	Navigation Radio																																																									
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																									
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																									
1	2013	Yukon XL	Body	Right Side Object Detection Module																																																									
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																									
1	2013	Yukon XL	Body	Theft Deterrent Module																																																									
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																									
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																									
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2014	Sierra	Chassis	Electronic Brake Control Module																																																									
1	2014	Sierra	Chassis	Parking Brake Control Module																																																									
1	2014	Sierra	Chassis	Power Steering Control Module																																																									
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2014	Sierra	Body	Body Control Module																																																									
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2014	Sierra	Body	Passenger Presence Module																																																									
1	2014	Sierra	Body	Instrument Cluster																																																									
1	2014	Sierra	Body	Radio Control																																																									
1	2014	Sierra	Body	HVAC Control																																																									
1	2014	Sierra	Body	Radio																																																									
1	2014	Sierra	Body	Amplifier																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2014	Sierra	Body	Media Disc Player																																																									
1	2014	Sierra	Body	Human Machine Interface Control Module																																																									
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																									
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																									
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																									
1	2014	Sierra	Body	Parking Assist Control Module																																																									
1	2014	Sierra	Body	Frontview Camera Module																																																									
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																									
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																									
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																									
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																									
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																									
1	2014	Sierra HD	Chassis	Suspension Control Module																																																									
1	2014	Sierra HD	Body	Body Control Module																																																									
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2014	Sierra HD	Body	Instrument Cluster																																																									
1	2014	Sierra HD	Body	Base Radio																																																									
1	2014	Sierra HD	Body	Navigation Radio																																																									
1	2014	Sierra HD	Body	Uplevel Radio																																																									
1	2014	Sierra HD	Body	Amplifier																																																									
1	2014	Sierra HD	Body	Rear Audio Control Module																																																									
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																									
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																									
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																									
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																									
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																									
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																									
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																									
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																									
1	2014	Sierra HD	Body	Seat Memory Control Module																																																									
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																									
1	2014	Sierra HD	Body	Parking Assist Control Module																																																									
1	2014	Sierra HD	Body	Theft Deterrent Module																																																									
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																									
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																									
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																									
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
1	2014	Yukon	Chassis	Electronic Brake Control Module																																																									
1	2014	Yukon	Chassis	Parking Brake Control Module																																																									
1	2014	Yukon	Chassis	Suspension Control Module																																																									
1	2014	Yukon	Body	Body Control Module																																																									
1	2014	Yukon	Body	Auxiliary Body Control Module																																																									
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2014	Yukon	Body	Passenger Presence Module																																																									
1	2014	Yukon	Body	Instrument Cluster																																																									
1	2014	Yukon	Body	Base Radio																																																									
1	2014	Yukon	Body	Navigation Radio																																																									
1	2014	Yukon	Body	Uplevel Radio																																																									
1	2014	Yukon	Body	Amplifier																																																									
1	2014	Yukon	Body	Rear Audio Control Module																																																									
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																																									
1	2014	Yukon	Body	Personal Audio Link Control Module																																																V									
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																									
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																									
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																									
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																									
1	2014	Yukon	Body	Liftgate Control Module																																																									
1	2014	Yukon	Body	Seat Memory Control Module																																																									
1	2014	Yukon	Body	Rear Seat Heating Control Module																																																									
1	2014	Yukon	Body	Assist Step Control Module																																																									
1	2014	Yukon	Body	Right Side Object Detection Control Module																																																									
1	2014	Yukon	Body	Left Side Object Detection Control Module																																																									
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																																									
1	2014	Yukon	Body	Parking Assist Control Module																																																									
1	2014	Yukon	Body	Theft Deterrent Module																																																									
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																									
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																									
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																									
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																									
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																									
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																									
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																																									
1	2014	Yukon XL	Chassis	Suspension Control Module																																																									
1	2014	Yukon XL	Body	Body Control Module																																																									
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																																									
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2014	Yukon XL	Body	Passenger Presence Module																																																									
1	2014	Yukon XL	Body	Instrument Cluster																																																									
1	2014	Yukon XL	Body	Base Radio																																																									
1	2014	Yukon XL	Body	Navigation Radio																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh:Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2014	Yukon XL	Body	Uplevel Radio																																																									
1	2014	Yukon XL	Body	Amplifier																																																									
1	2014	Yukon XL	Body	Rear Audio Control Module																																																									
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																									
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																															V										
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																									
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																									
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																									
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																									
1	2014	Yukon XL	Body	Liftgate Control Module																																																									
1	2014	Yukon XL	Body	Seat Memory Control Module																																																									
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																									
1	2014	Yukon XL	Body	Assist Step Control Module																																																									
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																									
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																									
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																									
1	2014	Yukon XL	Body	Parking Assist Control Module																																																									
1	2014	Yukon XL	Body	Theft Deterrent Module																																																									
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																									
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2015	Sierra	Chassis	Electronic Brake Control Module																																																									
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																									
1	2015	Sierra	Chassis	Power Steering Control Module																																																									
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2015	Sierra	Chassis	Suspension Control Module																																																									
1	2015	Sierra	Body	Body Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Sierra	Body	Passenger Presence Module																																																											
1	2015	Sierra	Body	Instrument Cluster																																																											
1	2015	Sierra	Body	Radio Controls																																																										
1	2015	Sierra	Body	HVAC Controls																																																										
1	2015	Sierra	Body	Radio																																																										
1	2015	Sierra	Body	Amplifier																																																										
1	2015	Sierra	Body	Media Disc Player																																																										
1	2015	Sierra	Body	Human Machine Interface Control Module																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2015	Sierra	Body	Parking Assist Control Module																																																										
1	2015	Sierra	Body	Frontview Camera Module																																																										
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																										
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																										
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																										
1	2015	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Yukon	Chassis	Parking Brake Control Module																																																										
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	Yukon	Chassis	Power Steering Control Module																																																										
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Yukon	Chassis	Suspension Control Module																																																										
1	2015	Yukon	Body	Body Control Module																																																										
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Yukon	Body	Passenger Presence Module																																																										
1	2015	Yukon	Body	Instrument Cluster																																																										
1	2015	Yukon	Body	Radio Controls																																																										
1	2015	Yukon	Body	HVAC Controls																																																										
1	2015	Yukon	Body	Radio																																																										
1	2015	Yukon	Body	Amplifier																																																										
1	2015	Yukon	Body	Media Disc Player																																																										
1	2015	Yukon	Body	Human Machine Interface Control Module																																																										
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2015	Yukon	Body	HVAC Control Module																																																									
1	2015	Yukon	Body	Liftgate Control Module																																																										
1	2015	Yukon	Body	Keyless Entry Control Module																																																										
1	2015	Yukon	Body	Assist Step Control Module																																																										
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon	Body	Parking Assist Control Module																																																										
1	2015	Yukon	Body	Frontview Camera Module																																																										
1	2015	Yukon	Body	Steering Column Lock Control Module																																																										
1	2015	Yukon	Body	Battery Energy Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	Yukon XL	Chassis	Power Steering Control Module																																																										
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Yukon XL	Chassis	Suspension Control Module																																																										
1	2015	Yukon XL	Body	Body Control Module																																																										
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Yukon XL	Body	Passenger Presence Module																																																										
1	2015	Yukon XL	Body	Instrument Cluster																																																										
1	2015	Yukon XL	Body	Radio Controls																																																										
1	2015	Yukon XL	Body	HVAC Controls																																																										
1	2015	Yukon XL	Body	Radio																																																										
1	2015	Yukon XL	Body	Amplifier																																																										
1	2015	Yukon XL	Body	Media Disc Player																																																										
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Yukon XL	Body	HVAC Control Module																																																										
1	2015	Yukon XL	Body	Liftgate Control Module																																																										
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
1	2015	Yukon XL	Body	Assist Step Control Module																																																										
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon XL	Body	Parking Assist Control Module																																																										
1	2015	Yukon XL	Body	Frontview Camera Module																																																										
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																									
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																									
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																									
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																									
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																									
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																									
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																									
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
1	2016	Sierra	Chassis	Electronic Brake Control Module																																																									
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																									
1	2016	Sierra	Chassis	Parking Brake Control Module																																																									
1	2016	Sierra	Chassis	Power Steering Control Module																																																									
1	2016	Sierra	Chassis	Power Steering Control Module																																																									
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
1	2016	Sierra	Chassis	Suspension Control Module																																																									
1	2016	Sierra	Body	Body Control Module																																																									
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
1	2016	Sierra	Body	Passenger Presence Module																																																									
1	2016	Sierra	Body	Instrument Cluster																																																									
1	2016	Sierra	Body	Radio Controls																																																									
1	2016	Sierra	Body	HVAC Controls																																																									
1	2016	Sierra	Body	Radio (IO3)																																																									
1	2016	Sierra	Body	Radio (IOB)																																																									
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																									
1	2016	Sierra	Body	Amplifier																																																									
1	2016	Sierra	Body	Media Disc Player																																																									
1	2016	Sierra	Body	Human Machine Interface Control Module																																																									
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																									
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																									
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																									
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																									
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																									
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																									
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																									
1	2016	Sierra	Body	Parking Assist Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2016	Sierra	Body	Frontview Camera Module																																																								
1	2016	Sierra	Body	Frontview Camera Module																																																								
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
1	2016	Yukon	Chassis	Electronic Brake Control Module																																																								
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																								
1	2016	Yukon	Chassis	Parking Brake Control Module																																																								
1	2016	Yukon	Chassis	Power Steering Control Module																																																								
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2016	Yukon	Chassis	Suspension Control Module																																																								
1	2016	Yukon	Body	Body Control Module																																																								
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
1	2016	Yukon	Body	Passenger Presence Module																																																								
1	2016	Yukon	Body	Instrument Cluster																																																								
1	2016	Yukon	Body	Radio Controls																																																								
1	2016	Yukon	Body	HVAC Controls																																																								
1	2016	Yukon	Body	Radio																																																								
1	2016	Yukon	Body	Amplifier																																																								
1	2016	Yukon	Body	Media Disc Player																																																								
1	2016	Yukon	Body	Human Machine Interface Control Module																																																								
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																								
1	2016	Yukon	Body	HVAC Control Module																																																								
1	2016	Yukon	Body	Liftgate Control Module																																																	V							
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																								
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																								
1	2016	Yukon	Body	Keyless Entry Control Module																																																								
1	2016	Yukon	Body	Assist Step Control Module																																																								
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																								
1	2016	Yukon	Body	Parking Assist Control Module																																																								
1	2016	Yukon	Body	Frontview Camera Module																																																								
1	2016	Yukon	Body	Steering Column Lock Control Module																																																								
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																								
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																								
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																								
1	2016	Yukon XL	Chassis	Power Steering Control Module																																																								
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																								
1	2016	Yukon XL	Chassis	Suspension Control Module																																																								
1	2016	Yukon XL	Body	Body Control Module																																																								
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
1	2016	Yukon XL	Body	Passenger Presence Module																																																									
1	2016	Yukon XL	Body	Instrument Cluster																																																										
1	2016	Yukon XL	Body	Radio Controls																																																										
1	2016	Yukon XL	Body	HVAC Controls																																																										
1	2016	Yukon XL	Body	Radio																																																										
1	2016	Yukon XL	Body	Amplifier																																																										
1	2016	Yukon XL	Body	Media Disc Player																																																										
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																										
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																										
1	2016	Yukon XL	Body	HVAC Control Module																																																										
1	2016	Yukon XL	Body	Liftgate Control Module																																																	V									
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																										
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																										
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																										
1	2016	Yukon XL	Body	Assist Step Control Module																																																										
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2016	Yukon XL	Body	Parking Assist Control Module																																																										
1	2016	Yukon XL	Body	Frontview Camera Module																																																										
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																										
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																				
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																														
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module											V																																														
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																									
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																									
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																									
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																									
2	2011	Sierra	Chassis	Electronic Suspension Control																																																									
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																									
2	2011	Sierra	Body	Amplifier (Bose)																																																									
2	2011	Sierra	Body	Body Control Module																																																									
2	2011	Sierra	Body	Body Control Module (aux.)																																																									
2	2011	Sierra	Body	Digital Radio Receiver																																																									
2	2011	Sierra	Body	Driver Door Switch																																																									
2	2011	Sierra	Body	HVAC Control Module Auto									V																																															
2	2011	Sierra	Body	HVAC Control Module Manual									V																																															
2	2011	Sierra	Body	Instrument Panel Cluster																																																									
2	2011	Sierra	Body	Memory Seat Module																																																									
2	2011	Sierra	Body	Park Assist Module																																																									
2	2011	Sierra	Body	Passenger Door Switch																																																									
2	2011	Sierra	Body	Passenger Presence System																																																									
2	2011	Sierra	Body	Radio																																																									
2	2011	Sierra	Body	Rear Heated Seat Module																																																									
2	2011	Sierra	Body	Rear HVAC/RSA																																																									
2	2011	Sierra	Body	Supplemental Inflatable Restraint																																																									
2	2011	Sierra	Body	Theft Deterrent Module																																																									
2	2011	Sierra Hybrid	Powertrain	Engine Control Module					V																																																				
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																									
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																									
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																									
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																									
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																									
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																									
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																									
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																									
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																									
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																									
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																									
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																									
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																									
2	2011	Sierra Hybrid	Body	Body Control Module																																																									
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																									
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																									
2	2011	Sierra Hybrid	Body	Driver Door Switch																																																									
2	2011	Sierra Hybrid	Body	Heated Seat Module																																																									
2	2011	Sierra Hybrid	Body	HVAC Control Module																																																									
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																									
2	2011	Sierra Hybrid	Body	Park Assist Module																																																									
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																																									
2	2011	Sierra Hybrid	Body	Passenger Presence System																																																									
2	2011	Sierra Hybrid	Body	Radio																																																									
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																									
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																								
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																								
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																								
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																														
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																								
2	2011	Yukon	Chassis	Electronic Brake Control Module																																																								
2	2011	Yukon	Chassis	Electronic Suspension Control																																																								
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																								
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																								
2	2011	Yukon	Body	Amplifier (Bose)																																																								
2	2011	Yukon	Body	Assist Step Controller																																																								
2	2011	Yukon	Body	Body Control Module																																																								
2	2011	Yukon	Body	Body Control Module (aux.)																																																								
2	2011	Yukon	Body	Digital Radio Receiver																																																								
2	2011	Yukon	Body	Driver Door Switch																																																								
2	2011	Yukon	Body	HVAC Control Module Auto									V																																															
2	2011	Yukon	Body	HVAC Control Module Manual																																																								
2	2011	Yukon	Body	Instrument Panel Cluster																																																								
2	2011	Yukon	Body	Left Side Object Detection Module																																																								
2	2011	Yukon	Body	Lift Gate Module																																																								
2	2011	Yukon	Body	Memory Seat Module																																																								
2	2011	Yukon	Body	Park Assist Module																																																								
2	2011	Yukon	Body	Passenger Door Switch																																																								
2	2011	Yukon	Body	Passenger Presence System																																																								
2	2011	Yukon	Body	Radio																																																								
2	2011	Yukon	Body	Rear Heated Seat Module																																																								
2	2011	Yukon	Body	Rear HVAC/RSA																																																								
2	2011	Yukon	Body	Right Side Object Detection Module																																																								
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																																								
2	2011	Yukon	Body	Theft Deterrent Module																																																								
2	2011	Yukon Hybrid	Powertrain	Engine Control Module				V																																																				
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																								
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																								
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																								
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																								
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																								
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																								
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																								
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																								
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																								
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																								
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																								
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																								
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																								
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																									
2	2011	Yukon Hybrid	Body	Body Control Module																																																										
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2011	Yukon Hybrid	Body	Driver Door Switch																																																										
2	2011	Yukon Hybrid	Body	Heated Seat Module																																																										
2	2011	Yukon Hybrid	Body	HVAC Control Module																																																										
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
2	2011	Yukon Hybrid	Body	Lift Gate Module																																																										
2	2011	Yukon Hybrid	Body	Park Assist Module																																																										
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																																										
2	2011	Yukon Hybrid	Body	Passenger Presence System																																																										
2	2011	Yukon Hybrid	Body	Radio																																																										
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module										V																																															
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																															
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																															
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																										
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon XL	Body	Amplifier (Bose)																																																										
2	2011	Yukon XL	Body	Assist Step Controller																																																										
2	2011	Yukon XL	Body	Body Control Module																																																										
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																										
2	2011	Yukon XL	Body	Digital Radio Receiver																																																										
2	2011	Yukon XL	Body	Driver Door Switch																																																										
2	2011	Yukon XL	Body	HVAC Control Module Auto									V																																																
2	2011	Yukon XL	Body	HVAC Control Module Manual																																																										
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																										
2	2011	Yukon XL	Body	Left Side Object Detection Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2011	Yukon XL	Body	Lift Gate Module																																																								
2	2011	Yukon XL	Body	Memory Seat Module																																																								
2	2011	Yukon XL	Body	Park Assist Module																																																								
2	2011	Yukon XL	Body	Passenger Door Switch																																																								
2	2011	Yukon XL	Body	Passenger Presence System																																																								
2	2011	Yukon XL	Body	Radio																																																								
2	2011	Yukon XL	Body	Rear Heated Seat Module																																																								
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																								
2	2011	Yukon XL	Body	Right Side Object Detection Module																																																								
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
2	2011	Yukon XL	Body	Theft Deterrent Module																																																								
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																		
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																													
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																													
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module											V																																												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																								
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																								
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																								
2	2012	Sierra	Chassis	Electronic Suspension Control																																																								
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																								
2	2012	Sierra	Body	Amplifier (Bose)																																																								
2	2012	Sierra	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2012	Sierra	Body	Body Control Module (aux.)																																																										
2	2012	Sierra	Body	Digital Radio Receiver																																																										
2	2012	Sierra	Body	Driver Door Switch																																																										
2	2012	Sierra	Body	HVAC Control Module Auto									V																																																	
2	2012	Sierra	Body	HVAC Control Module Manual									V																																																	
2	2012	Sierra	Body	Instrument Panel Cluster																																																										
2	2012	Sierra	Body	Memory Seat Module																																																										
2	2012	Sierra	Body	Park Assist Module																																																										
2	2012	Sierra	Body	Passenger Door Switch																																																										
2	2012	Sierra	Body	Passenger Presence System																																																										
2	2012	Sierra	Body	Radio																																																										
2	2012	Sierra	Body	Navigation Radio																																																										
2	2012	Sierra	Body	Rear Heated Seat Module																																																										
2	2012	Sierra	Body	Rear HVAC/RSA																																																										
2	2012	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra	Body	Theft Deterrent Module																																																										
2	2012	Sierra Hybrid	Powertrain	Engine Control Module					V																																																					
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Sierra Hybrid	Body	Body Control Module																																																										
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2012	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2012	Sierra Hybrid	Body	Park Assist Module																																																										
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2012	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2012	Sierra Hybrid	Body	Radio																																																										
2	2012	Sierra Hybrid	Body	Navigation Radio																																																										
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																									
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																									
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																															
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2012	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2012	Yukon	Chassis	Electronic Suspension Control																																																										
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																										
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Yukon	Body	Amplifier (Bose)																																																										
2	2012	Yukon	Body	Assist Step Controller																																																										
2	2012	Yukon	Body	Body Control Module																																																										
2	2012	Yukon	Body	Body Control Module (aux.)																																																										
2	2012	Yukon	Body	Digital Radio Receiver																																																										
2	2012	Yukon	Body	Driver Door Switch																																																										
2	2012	Yukon	Body	HVAC Control Module Auto									V																																																
2	2012	Yukon	Body	HVAC Control Module Manual																																																										
2	2012	Yukon	Body	Instrument Panel Cluster																																																										
2	2012	Yukon	Body	Left Side Object Detection Module																																																										
2	2012	Yukon	Body	Lift Gate Module																																																										
2	2012	Yukon	Body	Memory Seat Module																																																										
2	2012	Yukon	Body	Park Assist Module																																																										
2	2012	Yukon	Body	Passenger Door Switch																																																										
2	2012	Yukon	Body	Passenger Presence System																																																										
2	2012	Yukon	Body	Radio																																																										
2	2012	Yukon	Body	Navigation Radio																																																										
2	2012	Yukon	Body	Rear Heated Seat Module																																																										
2	2012	Yukon	Body	Rear HVAC/RSA																																																										
2	2012	Yukon	Body	Right Side Object Detection Module																																																										
2	2012	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2012	Yukon	Body	Theft Deterrent Module																																																										
2	2012	Yukon Hybrid	Powertrain	Engine Control Module					V																																																					
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2012	Yukon Hybrid	Body	Body Control Module																																																										
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Yukon Hybrid	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2012	Yukon Hybrid	Body	Heated Seat Module																																																								
2	2012	Yukon Hybrid	Body	HVAC Control Module																																																								
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																								
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																								
2	2012	Yukon Hybrid	Body	Lift Gate Module																																																								
2	2012	Yukon Hybrid	Body	Park Assist Module																																																								
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																																								
2	2012	Yukon Hybrid	Body	Passenger Presence System																																																								
2	2012	Yukon Hybrid	Body	Radio																																																								
2	2012	Yukon Hybrid	Body	Navigation Radio																																																								
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																								
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																								
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																								
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																								
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																								
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																														
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																								
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																														
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																								
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																								
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																								
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																								
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																								
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																								
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																								
2	2012	Yukon XL	Body	Amplifier (Bose)																																																								
2	2012	Yukon XL	Body	Assist Step Controller																																																								
2	2012	Yukon XL	Body	Body Control Module																																																								
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																								
2	2012	Yukon XL	Body	Digital Radio Receiver																																																								
2	2012	Yukon XL	Body	Driver Door Switch																																																								
2	2012	Yukon XL	Body	HVAC Control Module Auto									V																																														
2	2012	Yukon XL	Body	HVAC Control Module Manual																																																								
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																								
2	2012	Yukon XL	Body	Left Side Object Detection Module																																																								
2	2012	Yukon XL	Body	Lift Gate Module																																																								
2	2012	Yukon XL	Body	Memory Seat Module																																																								
2	2012	Yukon XL	Body	Park Assist Module																																																								
2	2012	Yukon XL	Body	Passenger Door Switch																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2012	Yukon XL	Body	Passenger Presence System																																																								
2	2012	Yukon XL	Body	Radio																																																								
2	2012	Yukon XL	Body	Navigation Radio																																																								
2	2012	Yukon XL	Body	Rear Heated Seat Module																																																								
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																								
2	2012	Yukon XL	Body	Right Side Object Detection Module																																																								
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
2	2012	Yukon XL	Body	Theft Deterrent Module																																																								
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																		
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																														
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																														
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module											V																																													
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																								
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																								
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																								
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																								
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																								
2	2013	Sierra	Chassis	Electronic Suspension Control																																																								
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																								
2	2013	Sierra	Body	Amplifier (Bose)																																																								
2	2013	Sierra	Body	Body Control Module																																																								
2	2013	Sierra	Body	Body Control Module (aux.)																																																								
2	2013	Sierra	Body	Digital Radio Receiver																																																								
2	2013	Sierra	Body	Driver Door Switch																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2013	Sierra	Body	HVAC Control Module Auto									V																																																		
2	2013	Sierra	Body	HVAC Control Module Manual									V																																																		
2	2013	Sierra	Body	Instrument Panel Cluster																																																											
2	2013	Sierra	Body	Memory Seat Module																																																											
2	2013	Sierra	Body	Park Assist Module																																																											
2	2013	Sierra	Body	Passenger Door Switch																																																											
2	2013	Sierra	Body	Passenger Presence System																																																											
2	2013	Sierra	Body	Radio																																																											
2	2013	Sierra	Body	Navigation Radio																																																											
2	2013	Sierra	Body	Rear Heated Seat Module																																																											
2	2013	Sierra	Body	Rear HVAC/RSA																																																											
2	2013	Sierra	Body	Supplemental Inflatable Restraint																																																											
2	2013	Sierra	Body	Theft Deterrent Module																																																											
2	2013	Sierra Hybrid	Powertrain	Engine Control Module					V																																																						
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																											
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																											
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																											
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																																											
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																											
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																											
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																											
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																											
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																											
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																											
2	2013	Sierra Hybrid	Body	Body Control Module																																																											
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																											
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																											
2	2013	Sierra Hybrid	Body	Driver Door Switch																																																											
2	2013	Sierra Hybrid	Body	Heated Seat Module																																																											
2	2013	Sierra Hybrid	Body	HVAC Control Module																																																											
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																											
2	2013	Sierra Hybrid	Body	Park Assist Module																																																											
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																																											
2	2013	Sierra Hybrid	Body	Passenger Presence System																																																											
2	2013	Sierra Hybrid	Body	Radio																																																											
2	2013	Sierra Hybrid	Body	Navigation Radio																																																											
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																											
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																											
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																											
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																											
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																											
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																	
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																											
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																											

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																																
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2013	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Body	Amplifier (Bose)																																																										
2	2013	Yukon	Body	Assist Step Controller																																																										
2	2013	Yukon	Body	Body Control Module																																																										
2	2013	Yukon	Body	Body Control Module (aux.)																																																										
2	2013	Yukon	Body	Digital Radio Receiver																																																										
2	2013	Yukon	Body	Driver Door Switch																																																										
2	2013	Yukon	Body	HVAC Control Module Auto									V																																																
2	2013	Yukon	Body	HVAC Control Module Manual																																																										
2	2013	Yukon	Body	Instrument Panel Cluster																																																										
2	2013	Yukon	Body	Left Side Object Detection Module																																																										
2	2013	Yukon	Body	Lift Gate Module																																																										
2	2013	Yukon	Body	Memory Seat Module																																																										
2	2013	Yukon	Body	Park Assist Module																																																										
2	2013	Yukon	Body	Passenger Door Switch																																																										
2	2013	Yukon	Body	Passenger Presence System																																																										
2	2013	Yukon	Body	Radio																																																										
2	2013	Yukon	Body	Navigation Radio																																																										
2	2013	Yukon	Body	Rear Heated Seat Module																																																										
2	2013	Yukon	Body	Rear HVAC/RSA																																																										
2	2013	Yukon	Body	Right Side Object Detection Module																																																										
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2013	Yukon	Body	Theft Deterrent Module																																																										
2	2013	Yukon Hybrid	Powertrain	Engine Control Module					V																																																					
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2013	Yukon Hybrid	Body	Body Control Module																																																										
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Yukon Hybrid	Body	Driver Door Switch																																																										
2	2013	Yukon Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2013	Yukon Hybrid	Body	HVAC Control Module																																																												
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
2	2013	Yukon Hybrid	Body	Lift Gate Module																																																												
2	2013	Yukon Hybrid	Body	Park Assist Module																																																												
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																																												
2	2013	Yukon Hybrid	Body	Passenger Presence System																																																												
2	2013	Yukon Hybrid	Body	Radio																																																												
2	2013	Yukon Hybrid	Body	Navigation Radio																																																												
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																												
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module										V																																																	
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																												
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																												
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module										V																																																	
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																												
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																												
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module										V																																																	
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																												
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
2	2013	Yukon XL	Body	Amplifier (Bose)																																																												
2	2013	Yukon XL	Body	Assist Step Controller																																																												
2	2013	Yukon XL	Body	Body Control Module																																																												
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																												
2	2013	Yukon XL	Body	Digital Radio Receiver																																																												
2	2013	Yukon XL	Body	Driver Door Switch																																																												
2	2013	Yukon XL	Body	HVAC Control Module Auto									V																																																		
2	2013	Yukon XL	Body	HVAC Control Module Manual																																																												
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																												
2	2013	Yukon XL	Body	Left Side Object Detection Module																																																												
2	2013	Yukon XL	Body	Lift Gate Module																																																												
2	2013	Yukon XL	Body	Memory Seat Module																																																												
2	2013	Yukon XL	Body	Park Assist Module																																																												
2	2013	Yukon XL	Body	Passenger Door Switch																																																												
2	2013	Yukon XL	Body	Passenger Presence System																																																												

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2013	Yukon XL	Body	Radio																																																								
2	2013	Yukon XL	Body	Navigation Radio																																																								
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																								
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																								
2	2013	Yukon XL	Body	Right Side Object Detection Module																																																								
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																								
2	2013	Yukon XL	Body	Theft Deterrent Module																																																								
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																								
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																								
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																								
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																								
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																								
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																								
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2014	Sierra	Chassis	Electronic Brake Control Module																																																								
2	2014	Sierra	Chassis	Parking Brake Control Module																																																								
2	2014	Sierra	Chassis	Power Steering Control Module																																																								
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																								
2	2014	Sierra	Body	Body Control Module																																																								
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
2	2014	Sierra	Body	Passenger Presence Module																																																								
2	2014	Sierra	Body	Instrument Cluster																																																								
2	2014	Sierra	Body	Radio Control																																																								
2	2014	Sierra	Body	HVAC Control																																																								
2	2014	Sierra	Body	Radio																																																								
2	2014	Sierra	Body	Amplifier																																																								
2	2014	Sierra	Body	Media Disc Player																																																								
2	2014	Sierra	Body	Human Machine Interface Control Module																																																								
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																								
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																								
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																								
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																								
2	2014	Sierra	Body	Parking Assist Control Module																																																								
2	2014	Sierra	Body	Frontview Camera Module																																																								
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																								
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																								
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																								
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																								
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2014	Sierra HD	Chassis	Suspension Control Module																																																									
2	2014	Sierra HD	Body	Body Control Module																																																										
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Sierra HD	Body	Instrument Cluster																																																										
2	2014	Sierra HD	Body	Base Radio																																																										
2	2014	Sierra HD	Body	Navigation Radio																																																										
2	2014	Sierra HD	Body	Uplevel Radio																																																										
2	2014	Sierra HD	Body	Amplifier																																																										
2	2014	Sierra HD	Body	Rear Audio Control Module																																																										
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																										
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																	V									
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																										
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Sierra HD	Body	Seat Memory Control Module																																																										
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																										
2	2014	Sierra HD	Body	Parking Assist Control Module																																																										
2	2014	Sierra HD	Body	Theft Deterrent Module																																																										
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																										
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2014	Yukon	Chassis	Parking Brake Control Module																																																										
2	2014	Yukon	Chassis	Suspension Control Module																																																										
2	2014	Yukon	Body	Body Control Module																																																										
2	2014	Yukon	Body	Auxiliary Body Control Module																																																										
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Yukon	Body	Passenger Presence Module																																																										
2	2014	Yukon	Body	Instrument Cluster																																																										
2	2014	Yukon	Body	Base Radio																																																										
2	2014	Yukon	Body	Navigation Radio																																																										
2	2014	Yukon	Body	Uplevel Radio																																																										
2	2014	Yukon	Body	Amplifier																																																										
2	2014	Yukon	Body	Rear Audio Control Module																																																										
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																										
2	2014	Yukon	Body	Personal Audio Link Control Module																																																	V									
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																									
2	2014	Yukon	Body	Liftgate Control Module																																																									
2	2014	Yukon	Body	Seat Memory Control Module																																																									
2	2014	Yukon	Body	Rear Seat Heating Control Module																																																									
2	2014	Yukon	Body	Assist Step Control Module																																																									
2	2014	Yukon	Body	Right Side Object Detection Control Module																																																									
2	2014	Yukon	Body	Left Side Object Detection Control Module																																																									
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																									
2	2014	Yukon	Body	Parking Assist Control Module																																																									
2	2014	Yukon	Body	Theft Deterrent Module																																																									
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																									
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																									
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																									
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																									
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																									
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																									
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																									
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																									
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																									
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																									
2	2014	Yukon XL	Chassis	Suspension Control Module																																																									
2	2014	Yukon XL	Body	Body Control Module																																																									
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																									
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2014	Yukon XL	Body	Passenger Presence Module																																																									
2	2014	Yukon XL	Body	Instrument Cluster																																																									
2	2014	Yukon XL	Body	Base Radio																																																									
2	2014	Yukon XL	Body	Navigation Radio																																																									
2	2014	Yukon XL	Body	Uplevel Radio																																																									
2	2014	Yukon XL	Body	Amplifier																																																									
2	2014	Yukon XL	Body	Rear Audio Control Module																																																									
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																									
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																									
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																									
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																									
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																									
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																									
2	2014	Yukon XL	Body	Liftgate Control Module																																																									
2	2014	Yukon XL	Body	Seat Memory Control Module																																																									
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																									
2	2014	Yukon XL	Body	Assist Step Control Module																																																									
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																									
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																									
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																									
2	2014	Yukon XL	Body	Parking Assist Control Module																																																									
2	2014	Yukon XL	Body	Theft Deterrent Module																																																									
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																									
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																									
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																									
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																									
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																									
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																									
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																									
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																									
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																									
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																									
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																									
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																									
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2015	Sierra	Chassis	Electronic Brake Control Module																																																									
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																									
2	2015	Sierra	Chassis	Power Steering Control Module																																																									
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2015	Sierra	Chassis	Suspension Control Module																																																									
2	2015	Sierra	Body	Body Control Module																																																									
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2015	Sierra	Body	Passenger Presence Module																																																									
2	2015	Sierra	Body	Instrument Cluster																																																									
2	2015	Sierra	Body	Radio Controls																																																									
2	2015	Sierra	Body	HVAC Controls																																																									
2	2015	Sierra	Body	Radio																																																									
2	2015	Sierra	Body	Amplifier																																																									
2	2015	Sierra	Body	Media Disc Player																																																									
2	2015	Sierra	Body	Human Machine Interface Control Module																																																									
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																									
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																									
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																									
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																									
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																									
2	2015	Sierra	Body	Parking Assist Control Module																																																									
2	2015	Sierra	Body	Frontview Camera Module																																																									
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																									
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																									
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																									
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																									
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																									
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																									
2	2015	Yukon	Chassis	Electronic Brake Control Module																																																									
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																									
2	2015	Yukon	Chassis	Parking Brake Control Module																																																									
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																									
2	2015	Yukon	Chassis	Power Steering Control Module																																																									
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2015	Yukon	Chassis	Suspension Control Module																																																									
2	2015	Yukon	Body	Body Control Module																																																									
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2015	Yukon	Body	Passenger Presence Module																																																									
2	2015	Yukon	Body	Instrument Cluster																																																									
2	2015	Yukon	Body	Radio Controls																																																									
2	2015	Yukon	Body	HVAC Controls																																																									
2	2015	Yukon	Body	Radio																																																									
2	2015	Yukon	Body	Amplifier																																																									
2	2015	Yukon	Body	Media Disc Player																																																									
2	2015	Yukon	Body	Human Machine Interface Control Module																																																									
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																									
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																									
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2015	Yukon	Body	HVAC Control Module																																																									
2	2015	Yukon	Body	Liftgate Control Module																																																									
2	2015	Yukon	Body	Keyless Entry Control Module																																																									
2	2015	Yukon	Body	Assist Step Control Module																																																									
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																									
2	2015	Yukon	Body	Parking Assist Control Module																																																									
2	2015	Yukon	Body	Frontview Camera Module																																																									
2	2015	Yukon	Body	Steering Column Lock Control Module																																																									
2	2015	Yukon	Body	Battery Energy Control Module																																																									
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																									
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																									
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																									
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																									
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																									
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																									
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
2	2015	Yukon XL	Chassis	Power Steering Control Module																																																										
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Yukon XL	Chassis	Suspension Control Module																																																										
2	2015	Yukon XL	Body	Body Control Module																																																										
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Yukon XL	Body	Passenger Presence Module																																																										
2	2015	Yukon XL	Body	Instrument Cluster																																																										
2	2015	Yukon XL	Body	Radio Controls																																																										
2	2015	Yukon XL	Body	HVAC Controls																																																										
2	2015	Yukon XL	Body	Radio																																																										
2	2015	Yukon XL	Body	Amplifier																																																										
2	2015	Yukon XL	Body	Media Disc Player																																																										
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Yukon XL	Body	HVAC Control Module																																																										
2	2015	Yukon XL	Body	Liftgate Control Module																																																										
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
2	2015	Yukon XL	Body	Assist Step Control Module																																																										
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
2	2015	Yukon XL	Body	Parking Assist Control Module																																																										
2	2015	Yukon XL	Body	Frontview Camera Module																																																										
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2016	Sierra	Chassis	Electronic Brake Control Module																																																								
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																								
2	2016	Sierra	Chassis	Parking Brake Control Module																																																								
2	2016	Sierra	Chassis	Power Steering Control Module																																																								
2	2016	Sierra	Chassis	Power Steering Control Module																																																								
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																								
2	2016	Sierra	Chassis	Suspension Control Module																																																								
2	2016	Sierra	Body	Body Control Module																																																								
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
2	2016	Sierra	Body	Passenger Presence Module																																																								
2	2016	Sierra	Body	Instrument Cluster																																																								
2	2016	Sierra	Body	Radio Controls																																																								
2	2016	Sierra	Body	HVAC Controls																																																								
2	2016	Sierra	Body	Radio (IO3)																																																								
2	2016	Sierra	Body	Radio (IOB)																																																								
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																								
2	2016	Sierra	Body	Amplifier																																																								
2	2016	Sierra	Body	Media Disc Player																																																								
2	2016	Sierra	Body	Human Machine Interface Control Module																																																								
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																								
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																								
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																								
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																								
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																								
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																								
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																								
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																								
2	2016	Sierra	Body	Parking Assist Control Module																																																								
2	2016	Sierra	Body	Frontview Camera Module																																																								
2	2016	Sierra	Body	Frontview Camera Module																																																								
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2016	Yukon	Chassis	Electronic Brake Control Module																																																								
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																								
2	2016	Yukon	Chassis	Parking Brake Control Module																																																								
2	2016	Yukon	Chassis	Power Steering Control Module																																																								
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																								
2	2016	Yukon	Chassis	Suspension Control Module																																																								
2	2016	Yukon	Body	Body Control Module																																																								
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
2	2016	Yukon	Body	Passenger Presence Module																																																								
2	2016	Yukon	Body	Instrument Cluster																																																								
2	2016	Yukon	Body	Radio Controls																																																								
2	2016	Yukon	Body	HVAC Controls																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
2	2016	Yukon	Body	Radio																																																								
2	2016	Yukon	Body	Amplifier																																																								
2	2016	Yukon	Body	Media Disc Player																																																								
2	2016	Yukon	Body	Human Machine Interface Control Module																																																								
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																								
2	2016	Yukon	Body	HVAC Control Module																																																								
2	2016	Yukon	Body	Liftgate Control Module																																																								
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																								
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																								
2	2016	Yukon	Body	Keyless Entry Control Module																																																								
2	2016	Yukon	Body	Assist Step Control Module																																																								
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																								
2	2016	Yukon	Body	Parking Assist Control Module																																																								
2	2016	Yukon	Body	Frontview Camera Module																																																								
2	2016	Yukon	Body	Steering Column Lock Control Module																																																								
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																								
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																								
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																								
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																								
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																								
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																								
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																								
2	2016	Yukon XL	Chassis	Power Steering Control Module																																																								
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																								
2	2016	Yukon XL	Chassis	Suspension Control Module																																																								
2	2016	Yukon XL	Body	Body Control Module																																																								
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
2	2016	Yukon XL	Body	Passenger Presence Module																																																								
2	2016	Yukon XL	Body	Instrument Cluster																																																								
2	2016	Yukon XL	Body	Radio Controls																																																								
2	2016	Yukon XL	Body	HVAC Controls																																																								
2	2016	Yukon XL	Body	Radio																																																								
2	2016	Yukon XL	Body	Amplifier																																																								
2	2016	Yukon XL	Body	Media Disc Player																																																								
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																								
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																								
2	2016	Yukon XL	Body	HVAC Control Module																																																								
2	2016	Yukon XL	Body	Liftgate Control Module																																																								
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																								
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																								
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																								
2	2016	Yukon XL	Body	Assist Step Control Module																																																								
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																								
2	2016	Yukon XL	Body	Parking Assist Control Module																																																								
2	2016	Yukon XL	Body	Frontview Camera Module																																																								
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																								
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
5	2011	ALL	Chassis	Electronic Brake Control Module																																																								
5	2011	ALL	Body	Body Control Module																																																								
5	2011	ALL	Body	Digital Radio Receiver																																																								
5	2011	ALL	Body	Generator Battery Control Module																																																								
5	2011	ALL	Body	Instrument Panel Cluster																																																								
5	2011	ALL	Body	Passenger Presence System																																																						V	
5	2011	ALL	Body	Personal Audio Link Module																										V																														
5	2011	ALL	Body	Base Radio																																																								
5	2011	ALL	Body	Uplevel Radio																																																								
5	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
5	2011	ALL	Body	Theft Deterrent Module																																																								
5	2011	ALL	Body	Vehicle Comm. Interface Module																																																								
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
5	2012	ALL	Chassis	Electronic Brake Control Module																																																								
5	2012	ALL	Body	Body Control Module																																																								
5	2012	ALL	Body	Digital Radio Receiver																																																								
5	2012	ALL	Body	Generator Battery Control Module																																																								
5	2012	ALL	Body	Instrument Panel Cluster																																																								
5	2012	ALL	Body	Passenger Presence System																																																						V	
5	2012	ALL	Body	Personal Audio Link Module																										V																														
5	2012	ALL	Body	Base Radio																																																								
5	2012	ALL	Body	Uplevel Radio																																																								
5	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
5	2012	ALL	Body	Theft Deterrent Module																																																								
5	2012	ALL	Body	Vehicle Comm. Interface Module																																																								
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
5	2015	Canyon	Powertrain	Chassis Control Module																																																								
5	2015	Canyon	Powertrain	Transfer Case Control Module																																																								
5	2015	Canyon	Chassis	Electronic Brake Control Module																																																								
5	2015	Canyon	Chassis	Power Steering Control Module																																																								
5	2015	Canyon	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
5	2015	Canyon	Body	Passenger Presence Module																																																										
5	2015	Canyon	Body	Radio																																																									
5	2015	Canyon	Body	Amplifier																																																									
5	2015	Canyon	Body	Human Machine Interface Control Module																																																										
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																																										
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
5	2015	Canyon	Body	Parking Assist Control Module																																																										
5	2015	Canyon	Body	Frontview Camera Module																																																										
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																										
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																										
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																										
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
5	2016	Canyon	Powertrain	Transfer Case Control Module																																																										
5	2016	Canyon	Chassis	Electronic Brake Control Module																																																										
5	2016	Canyon	Chassis	Power Steering Control Module																																																										
5	2016	Canyon	Body	Body Control Module																																																										
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
5	2016	Canyon	Body	Passenger Presence Module																																																										
5	2016	Canyon	Body	Trailer Interface Control Module																																																										
5	2016	Canyon	Body	Radio																																																										
5	2016	Canyon	Body	Amplifier																																																										
5	2016	Canyon	Body	Human Machine Interface Control Module																																																										
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																																										
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
5	2016	Canyon	Body	Frontview Camera Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
6	2011	ALL	Chassis	Electronic Brake Control Module																																																										
6	2011	ALL	Body	Body Control Module																																																										
6	2011	ALL	Body	Digital Radio Receiver																																																										
6	2011	ALL	Body	Generator Battery Control Module																																																										
6	2011	ALL	Body	Instrument Panel Cluster																																																										
6	2011	ALL	Body	Passenger Presence System																																																										
6	2011	ALL	Body	Personal Audio Link Module																										V																																
6	2011	ALL	Body	Base Radio																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
6	2011	ALL	Body	Uplevel Radio																																																								
6	2011	ALL	Body	Supplemental Inflatable Restraint																																																								
6	2011	ALL	Body	Theft Deterrent Module																																																								
6	2011	ALL	Body	Vehicle Comm. Interface Module																																																								
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																								
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																								
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																								
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																								
6	2012	ALL	Chassis	Electronic Brake Control Module																																																								
6	2012	ALL	Body	Body Control Module																																																								
6	2012	ALL	Body	Digital Radio Receiver																																																								
6	2012	ALL	Body	Generator Battery Control Module																																																								
6	2012	ALL	Body	Instrument Panel Cluster																																																								
6	2012	ALL	Body	Passenger Presence System																																																								
6	2012	ALL	Body	Personal Audio Link Module																										V																														
6	2012	ALL	Body	Base Radio																																																								
6	2012	ALL	Body	Uplevel Radio																																																								
6	2012	ALL	Body	Supplemental Inflatable Restraint																																																								
6	2012	ALL	Body	Theft Deterrent Module																																																								
6	2012	ALL	Body	Vehicle Comm. Interface Module																																																								
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																								
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																								
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
6	2015	Canyon	Powertrain	Chassis Control Module																																																								
6	2015	Canyon	Powertrain	Transfer Case Control Module																																																								
6	2015	Canyon	Chassis	Electronic Brake Control Module																																																								
6	2015	Canyon	Chassis	Power Steering Control Module																																																								
6	2015	Canyon	Body	Body Control Module																																																								
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
6	2015	Canyon	Body	Passenger Presence Module																																																								
6	2015	Canyon	Body	Radio																																																								
6	2015	Canyon	Body	Amplifier																																																								
6	2015	Canyon	Body	Human Machine Interface Control Module																																																								
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																																								
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																								
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																								
6	2015	Canyon	Body	Parking Assist Control Module																																																								
6	2015	Canyon	Body	Frontview Camera Module																																																								
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																								
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																								
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																								
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																								
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																								
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																								
6	2016	Canyon	Powertrain	Transfer Case Control Module																																																								
6	2016	Canyon	Chassis	Electronic Brake Control Module																																																								
6	2016	Canyon	Chassis	Power Steering Control Module																																																								
6	2016	Canyon	Body	Body Control Module																																																								
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
6	2016	Canyon	Body	Passenger Presence Module																																																								
6	2016	Canyon	Body	Trailer Interface Control Module																																																								
6	2016	Canyon	Body	Radio																																																								
6	2016	Canyon	Body	Amplifier																																																								
6	2016	Canyon	Body	Human Machine Interface Control Module																																																								
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																																								
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																								
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																								
6	2016	Canyon	Body	Frontview Camera Module																																																								
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																					V																			
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module										V																																														
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
7	2011	Express/Savana	Body	Body Control Module																																																								
7	2011	Express/Savana	Body	Digital Radio Receiver																																																								
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																								
7	2011	Express/Savana	Body	Passenger Presence System																																																								
7	2011	Express/Savana	Body	Radio																																																								
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
7	2011	Express/Savana	Body	Rollover Sensor																																																								
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
7	2011	Express/Savana	Body	Theft Deterrent Module																																																								
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																					V																			
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2011	Express Access/Savana Pro	Body	Body Control Module																																																									
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																									
7	2011	Express Access/Savana Pro	Body	Radio																																																									
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																									
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																			
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																									
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																									
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																									
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																									
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2012	Express/Savana	Body	Body Control Module																																																									
7	2012	Express/Savana	Body	Digital Radio Receiver																																																									
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																									
7	2012	Express/Savana	Body	Passenger Presence System																																																									
7	2012	Express/Savana	Body	Radio																																																								
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
7	2012	Express/Savana	Body	Rollover Sensor																																																									
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
7	2012	Express/Savana	Body	Theft Deterrent Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																						V																			
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
7	2012	Express Access/Savana Pro	Body	Body Control Module																																																								
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																								
7	2012	Express Access/Savana Pro	Body	Radio																																																								
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																					V																			
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
7	2013	Express/Savana	Body	Body Control Module																																																								
7	2013	Express/Savana	Body	Digital Radio Receiver																																																								
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
7	2013	Express/Savana	Body	Passenger Presence System																																																								
7	2013	Express/Savana	Body	Radio																																																								
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
7	2013	Express/Savana	Body	Rollover Sensor																																																								
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
7	2013	Express/Savana	Body	Theft Deterrent Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																					V																			
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module											V																																													
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																																								
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
7	2013	Express Access/Savana Pro	Body	Body Control Module																																																								
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																								
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																								
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																								
7	2013	Express Access/Savana Pro	Body	Radio																																																								
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																								
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																								
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																								
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																								
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																								
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																								
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																								
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																								
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
7	2014	Savana	Chassis	Electronic Brake Control Module																																																								
7	2014	Savana	Body	Body Control Module																																																								
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
7	2014	Savana	Body	Passenger Presence Module																																																								
7	2014	Savana	Body	Rollover Sensor Module																																																								
7	2014	Savana	Body	Instrument Cluster																																																								
7	2014	Savana	Body	Chime Alarm Control Module																																																								
7	2014	Savana	Body	Base Radio																																																								
7	2014	Savana	Body	Navigation Radio																																																								
7	2014	Savana	Body	Uplevel Radio																																																								
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																								
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																								
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
7	2014	Savana	Body	Auxiliary Heater Control Module																																																								
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																								
7	2014	Savana	Body	Parking Assist Control Module																																																								
7	2014	Savana	Body	Theft Deterrent Module																																																								
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
7	2015	Savana	Chassis	Electronic Brake Control Module																																																								
7	2015	Savana	Body	Body Control Module																																																								
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
7	2015	Savana	Body	Rollover Sensor Module																																																								
7	2015	Savana	Body	Instrument Cluster																																																								
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																								
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																								
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																								
7	2015	Savana	Body	Auxiliary Heater Control Module																																																								
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																								
7	2015	Savana	Body	Parking Assist Control Module																																																								
7	2015	Savana	Body	Theft Deterrent Module																																																								
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
7	2016	Savana	Chassis	Electronic Brake Control Module																																																								
7	2016	Savana	Body	Body Control Module																																																								
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
7	2016	Savana	Body	Instrument Cluster																																																								
7	2016	Savana	Body	Chime Alarm Control Module																																																								
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																								
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																								
7	2016	Savana	Body	Auxiliary Heater Control Module																																																								
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																								
7	2016	Savana	Body	Parking Assist Control Module																																																								
7	2016	Savana	Body	Theft Deterrent Module																																																								
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
8	2011	Express/Savana	Body	Body Control Module																																																								
8	2011	Express/Savana	Body	Digital Radio Receiver																																																								
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																								
8	2011	Express/Savana	Body	Passenger Presence System																																																								
8	2011	Express/Savana	Body	Radio																																																								
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
8	2011	Express/Savana	Body	Rollover Sensor																																																								
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
8	2011	Express/Savana	Body	Theft Deterrent Module																																																								
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
8	2011	Express Access/Savana Pro	Body	Body Control Module																																																								
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																								
8	2011	Express Access/Savana Pro	Body	Radio																																																								
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																								
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
8	2012	Express/Savana	Body	Body Control Module																																																								
8	2012	Express/Savana	Body	Digital Radio Receiver																																																								
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																								
8	2012	Express/Savana	Body	Passenger Presence System																																																								
8	2012	Express/Savana	Body	Radio																																																								
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
8	2012	Express/Savana	Body	Rollover Sensor																																																								
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
8	2012	Express/Savana	Body	Theft Deterrent Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
8	2012	Express Access/Savana Pro	Body	Body Control Module																																																								
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																								
8	2012	Express Access/Savana Pro	Body	Radio																																																								
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																								
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																								
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																								
8	2013	Express/Savana	Body	Body Control Module																																																								
8	2013	Express/Savana	Body	Digital Radio Receiver																																																								
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																								
8	2013	Express/Savana	Body	Navigation Radio																																																								
8	2013	Express/Savana	Body	Park Assist Module																																																								
8	2013	Express/Savana	Body	Passenger Presence System																																																								
8	2013	Express/Savana	Body	Radio																																																								
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																								
8	2013	Express/Savana	Body	Rollover Sensor																																																								
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																								
8	2013	Express/Savana	Body	Theft Deterrent Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																								
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																								
8	2013	Express Access/Savana Pro	Body	Body Control Module																																																								
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																								
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																								
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																								
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																																								
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																								
8	2013	Express Access/Savana Pro	Body	Radio																																																								
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																								
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																								
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																								
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																								
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																								
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																								
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																								
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																								
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																								
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																								
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																								
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
8	2014	Savana	Chassis	Electronic Brake Control Module																																																								
8	2014	Savana	Body	Body Control Module																																																								
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
8	2014	Savana	Body	Passenger Presence Module																																																								
8	2014	Savana	Body	Rollover Sensor Module																																																								
8	2014	Savana	Body	Instrument Cluster																																																								
8	2014	Savana	Body	Chime Alarm Control Module																																																								
8	2014	Savana	Body	Base Radio																																																								
8	2014	Savana	Body	Navigation Radio																																																								
8	2014	Savana	Body	Uplevel Radio																																																								
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																								
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																								
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																								
8	2014	Savana	Body	Auxiliary Heater Control Module																																																								
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																								
8	2014	Savana	Body	Parking Assist Control Module																																																								
8	2014	Savana	Body	Theft Deterrent Module																																																								
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
8	2015	Savana	Chassis	Electronic Brake Control Module																																																								
8	2015	Savana	Body	Body Control Module																																																								
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
8	2015	Savana	Body	Rollover Sensor Module																																																								
8	2015	Savana	Body	Instrument Cluster																																																								
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																								
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																								
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																								
8	2015	Savana	Body	Auxiliary Heater Control Module																																																								
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																								
8	2015	Savana	Body	Parking Assist Control Module																																																								
8	2015	Savana	Body	Theft Deterrent Module																																																								
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																								
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																								
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																								
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																								
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																								
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																								
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																								
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																								
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																								
8	2016	Savana	Chassis	Electronic Brake Control Module																																																								
8	2016	Savana	Body	Body Control Module																																																								
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																								
8	2016	Savana	Body	Instrument Cluster																																																								
8	2016	Savana	Body	Chime Alarm Control Module																																																								
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																								
8	2016	Savana	Body	Telematics Communication Interface Control Module																																																								
8	2016	Savana	Body	Auxiliary Heater Control Module																																																								
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																								
8	2016	Savana	Body	Parking Assist Control Module																																																								
8	2016	Savana	Body	Theft Deterrent Module																																																								
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																								
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																				V																																				
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																								
ALL	2004	ALL	Chassis	ABS																																																								
ALL	2004	ALL	Chassis	Air Suspension																																																								
ALL	2004	ALL	Body	Amplifier (Bose)																																																								
ALL	2004	ALL	Body	Body Control Module																																																								
ALL	2004	ALL	Body	Digital Radio Receiver																																																								
ALL	2004	ALL	Body	Driver Door Module																																																								
ALL	2004	ALL	Body	Driver Seat Module																								V																									V							
ALL	2004	ALL	Body	Heating and Air Conditioning																								V																											V	V				
ALL	2004	ALL	Body	Instrument Panel Cluster															V	V								V																																
ALL	2004	ALL	Body	OnStar																																																								
ALL	2004	ALL	Body	Passenger Door Module																																																						V	V	

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
ALL	2004	ALL	Body	Uplevel Radio																																																									
ALL	2004	ALL	Body	Navigation Radio																																																									
ALL	2004	ALL	Body	Rear Seat Audio																																																									
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																																									
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																				V																																					
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									
ALL	2005	ALL	Chassis	ABS																																																									
ALL	2005	ALL	Chassis	Air Suspension																																																									
ALL	2005	ALL	Body	Body Control Module																																																									
ALL	2005	ALL	Body	Digital Radio Receiver																																																									
ALL	2005	ALL	Body	Driver Door Module (SUV)																																																									
ALL	2005	ALL	Body	Driver Door Module (SUT)																																																									
ALL	2005	ALL	Body	Driver Seat Module																								V																										V							
ALL	2005	ALL	Body	Heating and Air Conditioning																								V																											V	V					
ALL	2005	ALL	Body	Instrument Panel Cluster																V	V							V																																	
ALL	2005	ALL	Body	Passenger Door Module																																																					V	V			
ALL	2005	ALL	Body	Uplevel Radio																																																									
ALL	2005	ALL	Body	Navigation Radio																																																									
ALL	2005	ALL	Body	Rear Seat Audio																																																									
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																																									
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																				V																																					
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									
ALL	2006	H2	Chassis	ABS																																																									
ALL	2006	H2	Chassis	Air Suspension																																																									
ALL	2006	H2	Body	Body Control Module																																																									
ALL	2006	H2	Body	Digital Radio Receiver																																																									
ALL	2006	H2	Body	Driver Door Module (SUV)																																																									
ALL	2006	H2	Body	Driver Door Module (SUT)																																																									
ALL	2006	H2	Body	Driver Seat Module																								V																										V							
ALL	2006	H2	Body	Heating and Air Conditioning																								V																											V	V					
ALL	2006	H2	Body	Instrument Panel Cluster																V	V							V																																	
ALL	2006	H2	Body	Passenger Door Module																																																					V	V			
ALL	2006	H2	Body	Uplevel Radio																																																									
ALL	2006	H2	Body	Navigation Radio																																																									
ALL	2006	H2	Body	Rear Seat Audio																																																									
ALL	2006	H2	Body	Supplemental Inflatable Restraint																																																									
ALL	2006	H3	Powertrain	Engine Control Module																																																									
ALL	2006	H3	Powertrain	Transmission Control Module																				V																																					
ALL	2006	H3	Powertrain	Transfer Case Control Module																																																									
ALL	2006	H3	Chassis	Antilock Brake System																																																									
ALL	2006	H3	Body	Body Control Module																																																									
ALL	2006	H3	Body	Digital Radio Receiver																																																									
ALL	2006	H3	Body	Instrument Panel Cluster																																																									
ALL	2006	H3	Body	Uplevel Radio	V																																																								
ALL	2006	H3	Body	Navigation Radio																																																									
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																																									
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																				V																																					
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
ALL	2007	H2	Chassis	ABS																																																										
ALL	2007	H2	Chassis	Air Suspension																																																										
ALL	2007	H2	Body	Amplifier (Bose)																																																										
ALL	2007	H2	Body	Body Control Module																																																										
ALL	2007	H2	Body	Digital Radio Receiver																																																										
ALL	2007	H2	Body	Driver Door Module (SUV)																																																										
ALL	2007	H2	Body	Driver Door Module (SUT)																																																										
ALL	2007	H2	Body	Driver Seat Module																								V																											V							
ALL	2007	H2	Body	HVAC Control Module																								V																												V	V					
ALL	2007	H2	Body	Instrument Panel Cluster																V	V							V																																		
ALL	2007	H2	Body	Passenger Door Module																																																			V				V	V		
ALL	2007	H2	Body	Uplevel Radio																																																										
ALL	2007	H2	Body	Navigation Radio																																																										
ALL	2007	H2	Body	Rear Seat Audio																																																										
ALL	2007	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																										
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																				V																																						
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																										
ALL	2007	H3	Chassis	EBCM																																																										
ALL	2007	H3	Body	Body Control Module (5GT)																																																										
ALL	2007	H3	Body	Body Control Module (ADM)																																																										
ALL	2007	H3	Body	Digital Radio Receiver																																																										
ALL	2007	H3	Body	Generator Battery Control Module																																																										
ALL	2007	H3	Body	Instrument Panel Cluster																																																										
ALL	2007	H3	Body	Personal Audio Link Module																										V																																
ALL	2007	H3	Body	Uplevel Radio	V																																																									
ALL	2007	H3	Body	Navigation Radio																																																										
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module										V																																																
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2008	H2	Chassis	Air SCM																																																										
ALL	2008	H2	Chassis	EBCM																																																										
ALL	2008	H2	Body	Amplifier (Bose)																																																										
ALL	2008	H2	Body	Body Control Module																																																										
ALL	2008	H2	Body	Digital Radio Receiver																																																										
ALL	2008	H2	Body	Driver Door Switch																																																										
ALL	2008	H2	Body	HVAC Control Module									V																																																	
ALL	2008	H2	Body	Instrument Panel Cluster																																																										
ALL	2008	H2	Body	Memory Seat Module																																																										
ALL	2008	H2	Body	Passenger Door Switch																																																										
ALL	2008	H2	Body	Radio																																																										
ALL	2008	H2	Body	Rear Heated Seat Module																																																										
ALL	2008	H2	Body	Rear HVAC/RSA																																																										
ALL	2008	H2	Body	Rollover Sensor																																																										
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	H2	Body	Theft Deterrent Module																																																										
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)																																																									
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																				V	V	V																																				
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																				V	V	V																																				
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																																										
ALL	2008	H3	Chassis	EBCM																																																										
ALL	2008	H3	Body	Body Control Module (5GT)																																																										
ALL	2008	H3	Body	Body Control Module (ADM)																																																										
ALL	2008	H3	Body	Digital Radio Receiver																																																										
ALL	2008	H3	Body	Generator Battery Control Module																																																										
ALL	2008	H3	Body	Instrument Panel Cluster																																																										
ALL	2008	H3	Body	Personal Audio Link Module																										V																																
ALL	2008	H3	Body	Uplevel Radio	V																																																									
ALL	2008	H3	Body	Navigation Radio																																																										
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2008	H3	Body	Theft Deterrent Module																																																										
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2009	H2	Chassis	Air SCM																																																										
ALL	2009	H2	Chassis	EBCM																																																										
ALL	2009	H2	Body	Amplifier (Bose)																																																										
ALL	2009	H2	Body	Body Control Module																																																										
ALL	2009	H2	Body	Digital Radio Receiver																																																										
ALL	2009	H2	Body	Driver Door Switch																																																										
ALL	2009	H2	Body	HVAC Control Module									V																																																
ALL	2009	H2	Body	Instrument Panel Cluster																																																										
ALL	2009	H2	Body	Memory Seat Module																																																										
ALL	2009	H2	Body	Passenger Door Switch																																																										
ALL	2009	H2	Body	Radio																																																										
ALL	2009	H2	Body	Rear Heated Seat Module																																																										
ALL	2009	H2	Body	Rear HVAC/RSA																																																										
ALL	2009	H2	Body	Rollover Sensor																																																										
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	H2	Body	Theft Deterrent Module																																																										
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																																								
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																																								
ALL	2009	H3	Chassis	EBCM																																																								
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																																								
ALL	2009	H3	Body	Body Control Module (ADM)																																																								
ALL	2009	H3	Body	Digital Radio Receiver																																																								
ALL	2009	H3	Body	Generator Battery Control Module																																																								
ALL	2009	H3	Body	Instrument Panel Cluster																																																								
ALL	2009	H3	Body	Personal Audio Link Module																										V																															
ALL	2009	H3	Body	Uplevel Radio	V																																																							
ALL	2009	H3	Body	Navigation Radio																																																								
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																																								
ALL	2009	H3	Body	Theft Deterrent Module																																																								
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																																								
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																								
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																								
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																								
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																								
ALL	2010	H2	Chassis	Air SCM																																																								
ALL	2010	H2	Chassis	EBCM																																																								
ALL	2010	H2	Body	Amplifier (Bose)																																																								
ALL	2010	H2	Body	Body Control Module																																																								
ALL	2010	H2	Body	Digital Radio Receiver																																																								
ALL	2010	H2	Body	Driver Door Switch																																																								
ALL	2010	H2	Body	HVAC Control Module									V																																														
ALL	2010	H2	Body	Instrument Panel Cluster																																																								
ALL	2010	H2	Body	Memory Seat Module																																																								
ALL	2010	H2	Body	Passenger Door Switch																																																								
ALL	2010	H2	Body	Personal Audio Link Module																										V																															
ALL	2010	H2	Body	Radio																																																								
ALL	2010	H2	Body	Rear Heated Seat Module																																																								
ALL	2010	H2	Body	Rear HVAC/RSA																																																								
ALL	2010	H2	Body	Rollover Sensor																																																								
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																																								
ALL	2010	H2	Body	Theft Deterrent Module																																																								
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																																								
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																								
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																								
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																								
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																								
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																								
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module																																																								
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																								
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																																								
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																																								
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																																								
ALL	2010	H3	Chassis	EBCM																																																								
ALL	2010	H3	Body	Body Control Module																																																								
ALL	2010	H3	Body	Digital Radio Receiver																																																								
ALL	2010	H3	Body	Generator Battery Control Module																																																								
ALL	2010	H3	Body	Instrument Panel Cluster																																																								

Engine type	Year	Model	System 1	System 2	Country Code	Chime Level	Loud Chime Volume	CMP Actuator	Cyl. Deactivation Data	Automatic Trans.	Manual Trans.	HVAC Sensor	Afterblow option	Cylinder Deactivation Data	induction Data	Preload Passenger presence system	3-2 Down Shift Data	Steering Column Lock	Twilight Sentinel Reprogram	Data 1	Data 2	RFA Information	Tire Information	3-2 Downshift Data	1-2 Adapt Data	2-3 Adapt Data	Recalibration	Input/Output	Setup New HVAC	Digital Radio Receiver	Cooling	Electrical	Steering Tuning Selection	Torque Sensor Calibration	Key Data	H02S Data	3-4 Adapt Data	Auto Transmisstion Data	Entry Control	TPM Learn Mode(Only 2008)	Ingition Data	EPM II Data	Exh.Aftertreatment Data	Stop/Start System Data	Reset Teen Driver Key PIN	Rocker Arm Actuator Data	Fuel Injector Learn	Throttle Actuator Reset	AWD Disabled-by-Malfunction Counter Reset	Vehicle Stability Data	Configuration/Reset Functions	Hands-Free Liftgate Sensor Control Module Calibration	Learn Sensor Location	Memory Data	Door Positions	HVAC Actuator recalibration	Program Individual Key Fob	Program All Key Fobs	DTC Erase and Re-zero PPS	Front Aux. Controls
ALL	2010	H3	Body	Personal Audio Link Module																										V																															
ALL	2010	H3	Body	Uplevel Radio	V																																																								
ALL	2010	H3	Body	Navigation Radio																																																									
ALL	2010	H3	Body	Supplemental Inflatable Restraint																																																									
ALL	2010	H3	Body	Theft Deterrent Module																																																									
ALL	2010	H3	Body	Vehicle Comm. Interface Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																		V	V																				
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																							
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																				V																				
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																							
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																							
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																							
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																							
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																							
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																							
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																							
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																							
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																							
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																							
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																							
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																							
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																							
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																							
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																					V																				
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																						V																			
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																					V		V																		
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																						V																		
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																							
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																							
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																						V																		
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																							
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																							
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																							
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																						
C	2004	ALL	Chassis	ESC																																																						
C	2004	ALL	Chassis	Rear Wheel Steering																																																						
C	2004	ALL	Chassis	Tire Pressure Monitor																																																						
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																						
C	2004	ALL	Chassis	VSES																																																						
C	2004	ALL	Body	Amplifier (Bose)																																																						
C	2004	ALL	Body	Body Control Module																																																						
C	2004	ALL	Body	CD Changer																																																						
C	2004	ALL	Body	Chime																																																						
C	2004	ALL	Body	Driver Door Module																																																						
C	2004	ALL	Body	Driver Seat Module																																																						
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																						
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																						
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																						
C	2004	ALL	Body	Instrument Panel Cluster																																																						
C	2004	ALL	Body	OnStar																																																						

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2004	ALL	Body	Passenger Door Module																																																												
C	2004	ALL	Body	Passenger Presence System																																																												
C	2004	ALL	Body	Radio Base																																																											
C	2004	ALL	Body	Radio Uplevel																																																											
C	2004	ALL	Body	Radio Navigation																																																											
C	2004	ALL	Body	Rear Aux. Climate Module	V																																																											
C	2004	ALL	Body	Rear HVAC																																																											
C	2004	ALL	Body	Rear Seat Audio																																																											
C	2004	ALL	Body	Rear Seat Entertainment																																																											
C	2004	ALL	Body	Supplemental Inflatable Restraint		V																																																									
C	2004	ALL	Body	Vehicle Theft Deterrent																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																			V	V																							
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																											
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																											
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																											
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																											
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																											
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																						V		V																				
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																							V																				
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																											
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																							V																				
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																											
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
C	2005	ALL	Chassis	ESC																																																										
C	2005	ALL	Chassis	Rear Wheel Steering																																																											
C	2005	ALL	Chassis	Tire Pressure Monitor																																																											
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2005	ALL	Chassis	VSES																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2005	ALL	Body	Amplifier (Bose)																																																										
C	2005	ALL	Body	Body Control Module																																																										
C	2005	ALL	Body	CD Changer																																																										
C	2005	ALL	Body	Chime																																																										
C	2005	ALL	Body	Disc Player and Video Display																																																										
C	2005	ALL	Body	Driver Door Module																																																										
C	2005	ALL	Body	Driver Seat Module																																																										
C	2005	ALL	Body	Generator Battery Control Module																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2005	ALL	Body	Instrument Panel Cluster																																																										
C	2005	ALL	Body	Passenger Door Module																																																										
C	2005	ALL	Body	Passenger Presence System																																																										
C	2005	ALL	Body	Base Radio																																																										
C	2005	ALL	Body	Uplevel Radio																																																										
C	2005	ALL	Body	Navigation Radio																																																										
C	2005	ALL	Body	Rear Aux. Climate Module	V																																																									
C	2005	ALL	Body	Rear HVAC																																																										
C	2005	ALL	Body	Rear Seat Audio																																																										
C	2005	ALL	Body	Supplemental Inflatable Restraint		V																																																								
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2005	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																		V	V																							
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																						V	V	V	V	V																
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																					V						V															
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																							V	V	V																	

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																							V	V	V	V	V												
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																						V						V											
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								V	V	V													
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																						
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																						V						V											
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																						
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																						
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																						
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																						
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																						
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																						
C	2006	ALL	Chassis	ESC																																																						
C	2006	ALL	Chassis	Tire Pressure Monitor																																																						
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																						
C	2006	ALL	Chassis	VSES																																																						
C	2006	ALL	Body	Amplifier (Bose)																																																						
C	2006	ALL	Body	Body Control Module																																																						
C	2006	ALL	Body	CD Changer																																																						
C	2006	ALL	Body	Chime																																																						
C	2006	ALL	Body	Disc Player and Video Display																																																						
C	2006	ALL	Body	Driver Door Module																																																						
C	2006	ALL	Body	Driver Seat Module																																																						
C	2006	ALL	Body	Generator Battery Control Module																																																						
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																						
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																						
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																						
C	2006	ALL	Body	Instrument Panel Cluster																																																						
C	2006	ALL	Body	Passenger Door Module																																																						
C	2006	ALL	Body	Passenger Presence System																																																						
C	2006	ALL	Body	Base Radio																																																						
C	2006	ALL	Body	Uplevel Radio																																																						
C	2006	ALL	Body	Navigation Radio																																																						
C	2006	ALL	Body	Rear Aux. Climate Module	V																																																					
C	2006	ALL	Body	Rear HVAC																																																						
C	2006	ALL	Body	Rear Seat Audio																																																						
C	2006	ALL	Body	Supplemental Inflatable Restraint			V																																																			
C	2006	ALL	Body	Vehicle Theft Deterrent																																																						
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																						
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																						
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V											
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																						
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																						
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																												V											
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																						
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																						
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																												V											
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																						
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																						
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																						
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																						
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																												V											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																													V														
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V			V	V												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V						V											
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																							V					V																
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																													V														
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																													V														
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																							
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES					V																																																							
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Sierra	Chassis	Electronic Suspension Control																																																												
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2007	Sierra	Body	Amplifier (Bose)																																																												
C	2007	Sierra	Body	Body Control Module																																																											
C	2007	Sierra	Body	Body Control Module (aux.)																																																											
C	2007	Sierra	Body	Digital Radio Receiver																																																											
C	2007	Sierra	Body	Driver Door Switch																																																											
C	2007	Sierra	Body	HVAC Control Module Auto						V																																								V													
C	2007	Sierra	Body	HVAC Control Module Manual						V																																																					
C	2007	Sierra	Body	Instrument Panel Cluster																																																											
C	2007	Sierra	Body	Memory Seat Module							V																																																				
C	2007	Sierra	Body	Park Assist Module								V																																																		
C	2007	Sierra	Body	Passenger Door Switch																																																											
C	2007	Sierra	Body	Passenger Presence System																																																											
C	2007	Sierra	Body	Radio																																																										
C	2007	Sierra	Body	Rear Heated Seat Module																																																											
C	2007	Sierra	Body	Rear HVAC/RSA																																																											
C	2007	Sierra	Body	Rollover Sensor																																																											
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																																											
C	2007	Sierra	Body	Theft Deterrent Module																																																											
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																													V														
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																													V														
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																													V														
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																							
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES					V																																																							
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2007	Yukon	Chassis	Electronic Suspension Control																																																											
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																											
C	2007	Yukon	Body	Amplifier (Bose)																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2007	Yukon	Body	Assist Step Controller																																																											
C	2007	Yukon	Body	Body Control Module																																																											
C	2007	Yukon	Body	Body Control Module (aux.)																																																											
C	2007	Yukon	Body	Digital Radio Receiver																																																											
C	2007	Yukon	Body	Driver Door Switch																																																											
C	2007	Yukon	Body	HVAC Control Module Auto						V																																											V										
C	2007	Yukon	Body	HVAC Control Module Manual						V																																																					
C	2007	Yukon	Body	Instrument Panel Cluster																																																											
C	2007	Yukon	Body	Lift Gate Module																																																											
C	2007	Yukon	Body	Memory Seat Module							V																																																			
C	2007	Yukon	Body	Park Assist Module								V																																																		
C	2007	Yukon	Body	Passenger Door Switch																																																											
C	2007	Yukon	Body	Passenger Presence System																																																											
C	2007	Yukon	Body	Radio																																																											
C	2007	Yukon	Body	Rear Heated Seat Module																																																											
C	2007	Yukon	Body	Rear HVAC/RSA																																																											
C	2007	Yukon	Body	Rollover Sensor																																																											
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																																											
C	2007	Yukon	Body	Theft Deterrent Module																																																											
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																	V										
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																	V										
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																	V										
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																	V										
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																						
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																											
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																											
C	2007	Yukon XL	Body	Amplifier (Bose)																																																											
C	2007	Yukon XL	Body	Assist Step Controller																																																											
C	2007	Yukon XL	Body	Body Control Module																																																											
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																											
C	2007	Yukon XL	Body	Digital Radio Receiver																																																											
C	2007	Yukon XL	Body	Driver Door Switch																																																											
C	2007	Yukon XL	Body	HVAC Control Module Auto						V																																											V										
C	2007	Yukon XL	Body	HVAC Control Module Manual						V																																																					
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																											
C	2007	Yukon XL	Body	Lift Gate Module																																																											
C	2007	Yukon XL	Body	Memory Seat Module							V																																																				
C	2007	Yukon XL	Body	Park Assist Module								V																																																		
C	2007	Yukon XL	Body	Passenger Door Switch																																																											
C	2007	Yukon XL	Body	Passenger Presence System																																																											
C	2007	Yukon XL	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2007	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2007	Yukon XL	Body	Rollover Sensor																																																												
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2007	Yukon XL	Body	Theft Deterrent Module																																																												
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V										
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V								
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																							V					V													
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES					V																																																						
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																											
C	2008	Sierra	Chassis	Electronic Suspension Control																																																											
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																											
C	2008	Sierra	Body	Amplifier (Bose)																																																											
C	2008	Sierra	Body	Body Control Module																																																										
C	2008	Sierra	Body	Body Control Module (aux.)																																																										
C	2008	Sierra	Body	Digital Radio Receiver																																																										
C	2008	Sierra	Body	Driver Door Switch																																																										
C	2008	Sierra	Body	HVAC Control Module Auto						V																																											V										
C	2008	Sierra	Body	HVAC Control Module Manual						V																																																				
C	2008	Sierra	Body	Instrument Panel Cluster																																																										
C	2008	Sierra	Body	Memory Seat Module							V																																																		
C	2008	Sierra	Body	Park Assist Module								V																																																	
C	2008	Sierra	Body	Passenger Door Switch																																																										
C	2008	Sierra	Body	Passenger Presence System																																																										
C	2008	Sierra	Body	Radio																																																										
C	2008	Sierra	Body	Rear Heated Seat Module																																																										
C	2008	Sierra	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2008	Sierra	Body	Rollover Sensor																																																										
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2008	Sierra	Body	Theft Deterrent Module																																																										
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2008	Yukon	Chassis	Electronic Brake Control Module					V																																																					
C	2008	Yukon	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon	Body	Amplifier (Bose)																																																										
C	2008	Yukon	Body	Assist Step Controller																																																										
C	2008	Yukon	Body	Body Control Module																																																										
C	2008	Yukon	Body	Body Control Module (aux.)																																																										
C	2008	Yukon	Body	Digital Radio Receiver																																																										
C	2008	Yukon	Body	Driver Door Switch																																																										
C	2008	Yukon	Body	HVAC Control Module Auto						V																																									V											
C	2008	Yukon	Body	HVAC Control Module Manual						V																																																				
C	2008	Yukon	Body	Instrument Panel Cluster																																																										
C	2008	Yukon	Body	Lift Gate Module																																																										
C	2008	Yukon	Body	Memory Seat Module							V																																																			
C	2008	Yukon	Body	Park Assist Module								V																																																		
C	2008	Yukon	Body	Passenger Door Switch																																																										
C	2008	Yukon	Body	Passenger Presence System																																																										
C	2008	Yukon	Body	Radio																																																										
C	2008	Yukon	Body	Rear Heated Seat Module																																																										
C	2008	Yukon	Body	Rear HVAC/RSA																																																										
C	2008	Yukon	Body	Rollover Sensor																																																										
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																																										
C	2008	Yukon	Body	Theft Deterrent Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																															V	V		V	V							
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																				V	V				
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																		V																						V	V
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																										
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																										
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																												
C	2008	Yukon Hybrid	Body	Body Control Module																																																												
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																												
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																												
C	2008	Yukon Hybrid	Body	HVAC Control Module						V																																											V				V						
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
C	2008	Yukon Hybrid	Body	Lift Gate Module																																																												
C	2008	Yukon Hybrid	Body	Memory Seat Module							V																																																					
C	2008	Yukon Hybrid	Body	Park Assist Module								V																																																				
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																												
C	2008	Yukon Hybrid	Body	Passenger Presence System																																																												
C	2008	Yukon Hybrid	Body	Radio																																																												
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																												
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW				V																																																								
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon XL	Body	Amplifier (Bose)																																																												
C	2008	Yukon XL	Body	Assist Step Controller																																																												
C	2008	Yukon XL	Body	Body Control Module																																																												
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2008	Yukon XL	Body	Digital Radio Receiver																																																												
C	2008	Yukon XL	Body	Driver Door Switch																																																												
C	2008	Yukon XL	Body	HVAC Control Module Auto						V																																											V										
C	2008	Yukon XL	Body	HVAC Control Module Manual						V																																																					
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2008	Yukon XL	Body	Lift Gate Module																																																												
C	2008	Yukon XL	Body	Memory Seat Module							V																																																					

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2008	Yukon XL	Body	Park Assist Module								V																																																		
C	2008	Yukon XL	Body	Passenger Door Switch																																																										
C	2008	Yukon XL	Body	Passenger Presence System																																																										
C	2008	Yukon XL	Body	Radio																																																									
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2008	Yukon XL	Body	Rollover Sensor																																																										
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
C	2008	Yukon XL	Body	Theft Deterrent Module																																																										
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																										
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																													V														
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V									
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																							V					V														
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual																																																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES					V																																																					
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES					V																																																					
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																						
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
C	2009	Sierra	Chassis	Electronic Suspension Control																																																										
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																										
C	2009	Sierra	Body	Amplifier (Bose)																																																										
C	2009	Sierra	Body	Body Control Module																																																										
C	2009	Sierra	Body	Body Control Module (aux.)																																																										
C	2009	Sierra	Body	Digital Radio Receiver																																																										
C	2009	Sierra	Body	Driver Door Switch																																																										
C	2009	Sierra	Body	HVAC Control Module Auto						V																																																				

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2009	Sierra	Body	HVAC Control Module Manual						V																																																					
C	2009	Sierra	Body	Instrument Panel Cluster																																																												
C	2009	Sierra	Body	Memory Seat Module							V																																																				
C	2009	Sierra	Body	Park Assist Module								V																																																			
C	2009	Sierra	Body	Passenger Door Switch																																																												
C	2009	Sierra	Body	Passenger Presence System																																																												
C	2009	Sierra	Body	Radio																																																											
C	2009	Sierra	Body	Rear Heated Seat Module																																																												
C	2009	Sierra	Body	Rear HVAC/RSA																																																												
C	2009	Sierra	Body	Rollover Sensor																																																												
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2009	Sierra	Body	Theft Deterrent Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																	V	V		V	V					
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																						V	V			
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																						V	V
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																												
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																												
C	2009	Sierra Hybrid	Body	Body Control Module																																																												
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																												
C	2009	Sierra Hybrid	Body	Driver Door Switch																																																												
C	2009	Sierra Hybrid	Body	HVAC Control Module						V																																											V			V						
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
C	2009	Sierra Hybrid	Body	Memory Seat Module							V																																																					
C	2009	Sierra Hybrid	Body	Park Assist Module								V																																																				
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																																												
C	2009	Sierra Hybrid	Body	Passenger Presence System																																																												
C	2009	Sierra Hybrid	Body	Radio																																																												
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																												
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																													V															
C	2009	Yukon	Chassis	Electronic Brake Control Module					V																																																							
C	2009	Yukon	Chassis	Electronic Suspension Control																																																													
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																												
C	2009	Yukon	Body	Amplifier (Bose)																																																												
C	2009	Yukon	Body	Assist Step Controller																																																												
C	2009	Yukon	Body	Body Control Module																																																												
C	2009	Yukon	Body	Body Control Module (aux.)																																																												
C	2009	Yukon	Body	Digital Radio Receiver																																																												
C	2009	Yukon	Body	Driver Door Switch																																																												
C	2009	Yukon	Body	HVAC Control Module Auto						V																																									V													
C	2009	Yukon	Body	HVAC Control Module Manual						V																																																						
C	2009	Yukon	Body	Instrument Panel Cluster																																																												
C	2009	Yukon	Body	Left Side Object Detection Module																																																												
C	2009	Yukon	Body	Lift Gate Module																																																												
C	2009	Yukon	Body	Memory Seat Module							V																																																					
C	2009	Yukon	Body	Park Assist Module								V																																																			
C	2009	Yukon	Body	Passenger Door Switch																																																												
C	2009	Yukon	Body	Passenger Presence System																																																												
C	2009	Yukon	Body	Radio																																																											
C	2009	Yukon	Body	Rear Heated Seat Module																																																												
C	2009	Yukon	Body	Rear HVAC/RSA																																																												
C	2009	Yukon	Body	Right Side Object Detection Module																																																												
C	2009	Yukon	Body	Rollover Sensor																																																												
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																																												
C	2009	Yukon	Body	Theft Deterrent Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																V	V		V	V						
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																								V	V		
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																						V	V
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																												
C	2009	Yukon Hybrid	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																												
C	2009	Yukon Hybrid	Body	Driver Door Switch																																																												
C	2009	Yukon Hybrid	Body	Heated Seat Module																																																												
C	2009	Yukon Hybrid	Body	HVAC Control Module						V																																									V			V								
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
C	2009	Yukon Hybrid	Body	Park Assist Module								V																																																			
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																																												
C	2009	Yukon Hybrid	Body	Passenger Presence System																																																												
C	2009	Yukon Hybrid	Body	Radio																																																												
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																												
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																												
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW					V																																																							
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2009	Yukon XL	Body	Amplifier (Bose)																																																												
C	2009	Yukon XL	Body	Assist Step Controller																																																												
C	2009	Yukon XL	Body	Body Control Module																																																												
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2009	Yukon XL	Body	Digital Radio Receiver																																																												
C	2009	Yukon XL	Body	Driver Door Switch																																																												
C	2009	Yukon XL	Body	HVAC Control Module Auto						V																																									V											
C	2009	Yukon XL	Body	HVAC Control Module Manual						V																																																					
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2009	Yukon XL	Body	Left Side Object Detection Module																																																												
C	2009	Yukon XL	Body	Lift Gate Module																																																												
C	2009	Yukon XL	Body	Memory Seat Module							V																																																				

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2009	Yukon XL	Body	Park Assist Module								V																																																			
C	2009	Yukon XL	Body	Passenger Door Switch																																																											
C	2009	Yukon XL	Body	Passenger Presence System																																																											
C	2009	Yukon XL	Body	Radio																																																										
C	2009	Yukon XL	Body	Rear Heated Seat Module																																																											
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																											
C	2009	Yukon XL	Body	Right Side Object Detection Module																																																											
C	2009	Yukon XL	Body	Rollover Sensor																																																											
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
C	2009	Yukon XL	Body	Theft Deterrent Module																																																											
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																											
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module											V	V																																															
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V											
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V									
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																							V					V															
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																															
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES					V																																																						
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES					V																																																						
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
C	2010	Sierra	Chassis	Electronic Suspension Control																																																											
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																											
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Sierra	Body	Amplifier (Bose)																																																											
C	2010	Sierra	Body	Body Control Module																																																										
C	2010	Sierra	Body	Body Control Module (aux.)																																																											
C	2010	Sierra	Body	Digital Radio Receiver																																																											
C	2010	Sierra	Body	Driver Door Switch																																																											
C	2010	Sierra	Body	HVAC Control Module Auto						V																																										V											
C	2010	Sierra	Body	HVAC Control Module Manual						V																																																					
C	2010	Sierra	Body	Instrument Panel Cluster																																																											
C	2010	Sierra	Body	Memory Seat Module							V																																																				
C	2010	Sierra	Body	Park Assist Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2010	Sierra	Body	Passenger Door Switch																																																											
C	2010	Sierra	Body	Passenger Presence System																																																											
C	2010	Sierra	Body	Radio																																																										
C	2010	Sierra	Body	Rear Heated Seat Module																																																										
C	2010	Sierra	Body	Rear HVAC/RSA																																																										
C	2010	Sierra	Body	Supplemental Inflatable Restraint																																																										
C	2010	Sierra	Body	Theft Deterrent Module																																																										
C	2010	Sierra Hybrid	Powertrain	Engine Control Module																																															V	V		V	V				
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																				V	V			
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																		V																						V	V
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																										
C	2010	Sierra Hybrid	Body	Body Control Module																																																										
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																										
C	2010	Sierra Hybrid	Body	Driver Door Switch																																																										
C	2010	Sierra Hybrid	Body	Heated Seat Module																																																										
C	2010	Sierra Hybrid	Body	HVAC Control Module						V																																											V								
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
C	2010	Sierra Hybrid	Body	Park Assist Module																																																										
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																																										
C	2010	Sierra Hybrid	Body	Passenger Presence System																																																										
C	2010	Sierra Hybrid	Body	Radio																																																										
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Yukon	Chassis	Electronic Brake Control Module					V																																																					
C	2010	Yukon	Chassis	Electronic Suspension Control																																																										
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon	Body	Amplifier (Bose)																																																										
C	2010	Yukon	Body	Assist Step Controller																																																										
C	2010	Yukon	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2010	Yukon	Body	Body Control Module (aux.)																																																												
C	2010	Yukon	Body	Digital Radio Receiver																																																												
C	2010	Yukon	Body	Driver Door Switch																																																												
C	2010	Yukon	Body	HVAC Control Module Auto						V																																									V												
C	2010	Yukon	Body	HVAC Control Module Manual						V																																																					
C	2010	Yukon	Body	Instrument Panel Cluster																																																												
C	2010	Yukon	Body	Left Side Object Detection Module																																																												
C	2010	Yukon	Body	Lift Gate Module																																																												
C	2010	Yukon	Body	Memory Seat Module							V																																																				
C	2010	Yukon	Body	Park Assist Module																																																											
C	2010	Yukon	Body	Passenger Door Switch																																																											
C	2010	Yukon	Body	Passenger Presence System																																																											
C	2010	Yukon	Body	Radio																																																											
C	2010	Yukon	Body	Rear Heated Seat Module																																																											
C	2010	Yukon	Body	Rear HVAC/RSA																																																											
C	2010	Yukon	Body	Right Side Object Detection Module																																																											
C	2010	Yukon	Body	Supplemental Inflatable Restraint																																																											
C	2010	Yukon	Body	Theft Deterrent Module																																																											
C	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																V	V		V	V				
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																				V	V			
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																		V																						V	V
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																											
C	2010	Yukon Hybrid	Body	Body Control Module																																																											
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																											
C	2010	Yukon Hybrid	Body	Driver Door Switch																																																											
C	2010	Yukon Hybrid	Body	Heated Seat Module																																																											
C	2010	Yukon Hybrid	Body	HVAC Control Module						V																																												V								
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
C	2010	Yukon Hybrid	Body	Lift Gate Module																																																											
C	2010	Yukon Hybrid	Body	Park Assist Module																																																											
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																																											
C	2010	Yukon Hybrid	Body	Passenger Presence System																																																											
C	2010	Yukon Hybrid	Body	Radio																																																											
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																											
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																										
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																														
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW					V																																																					
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																										
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																										
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																										
C	2010	Yukon XL	Body	Amplifier (Bose)																																																										
C	2010	Yukon XL	Body	Assist Step Controller																																																										
C	2010	Yukon XL	Body	Body Control Module																																																										
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																										
C	2010	Yukon XL	Body	Digital Radio Receiver																																																										
C	2010	Yukon XL	Body	Driver Door Switch																																																										
C	2010	Yukon XL	Body	HVAC Control Module Auto						V																																								V												
C	2010	Yukon XL	Body	HVAC Control Module Manual						V																																																				
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																										
C	2010	Yukon XL	Body	Left Side Object Detection Module																																																										
C	2010	Yukon XL	Body	Lift Gate Module																																																										
C	2010	Yukon XL	Body	Memory Seat Module							V																																																			
C	2010	Yukon XL	Body	Park Assist Module																																																										
C	2010	Yukon XL	Body	Passenger Door Switch																																																										
C	2010	Yukon XL	Body	Passenger Presence System																																																										
C	2010	Yukon XL	Body	Radio																																																										
C	2010	Yukon XL	Body	Rear Heated Seat Module																																																										
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																										
C	2010	Yukon XL	Body	Right Side Object Detection Module																																																										
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
C	2010	Yukon XL	Body	Theft Deterrent Module																																																										
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																										
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																										
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2008	ALL	Chassis	Electronic Brake Control Module																																																										
D	2008	ALL	Body	Body Control Module																																																										
D	2008	ALL	Body	Body Control Module (aux.)																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
D	2008	ALL	Body	Headlamp Control Module																																																										
D	2008	ALL	Body	HVAC Control Module Auto																																																										
D	2008	ALL	Body	Instrument Panel Cluster																																																										
D	2008	ALL	Body	Park Assist Module																																																										
D	2008	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
D	2008	ALL	Body	Theft Deterrent Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2009	ALL	Chassis	Electronic Brake Control Module																																																										
D	2009	ALL	Body	Body Control Module																																																										
D	2009	ALL	Body	Body Control Module (aux.)																																																										
D	2009	ALL	Body	Headlamp Control Module																																																										
D	2009	ALL	Body	HVAC Control Module Auto																																																										
D	2009	ALL	Body	Instrument Panel Cluster																																																										
D	2009	ALL	Body	Park Assist Module																																																										
D	2009	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
D	2009	ALL	Body	Theft Deterrent Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																										
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																										
D	2010	ALL	Chassis	Electronic Brake Control Module																																																										
D	2010	ALL	Body	Body Control Module																																																										
D	2010	ALL	Body	Body Control Module (aux.)																																																										
D	2010	ALL	Body	Headlamp Control Module																																																										
D	2010	ALL	Body	HVAC Control Module Auto																																																										
D	2010	ALL	Body	Instrument Panel Cluster																																																										
D	2010	ALL	Body	Park Assist Module																																																										
D	2010	ALL	Body	Remote Control Door Lock Receiver																																																										
D	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																										
G	2004	Express/Savana	Body	Body Control Module																																																										
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2004	Express/Savana	Body	OnStar																																																										
G	2004	Express/Savana	Body	Base Radio																																																										
G	2004	Express/Savana	Body	Uplevel Radio																																																										
G	2004	Express/Savana	Body	Remote Function Actuation																																																										
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint		V																																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																																										
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint		V																																																								
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																											
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																											
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																											
G	2005	Express/Savana	Chassis	VSES																																																											
G	2005	Express/Savana	Body	Body Control Module																																																											
G	2005	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																											
G	2005	Express/Savana	Body	Base Radio																																																											
G	2005	Express/Savana	Body	Uplevel Radio																																																											
G	2005	Express/Savana	Body	Remote Function Actuation																																																											
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint		V																																																									
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																											
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																											
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																											
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																											
G	2005	Express Access/Savana Pro	Chassis	VSES																																																											
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
G	2005	Express Access/Savana Pro	Body	Base Radio																																																											
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																											
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																											
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint		V																																																									
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																											
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																							V				V															
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								V	V	V																
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2006	Express/Savana	Chassis	VSES																																																										
G	2006	Express/Savana	Body	Body Control Module																																																										
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2006	Express/Savana	Body	Passenger Presence System																																																										
G	2006	Express/Savana	Body	Base Radio																																																										
G	2006	Express/Savana	Body	Uplevel Radio																																																										
G	2006	Express/Savana	Body	Remote Function Actuation																																																										
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint		V																																																								
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																							V				V															
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								V	V	V																
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2006	Express Access/Savana Pro	Chassis	VSES																																																										
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2006	Express Access/Savana Pro	Body	Base Radio																																																										
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint		V																																																								
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																							V	V	V	V	V															
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								V	V	V																
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																								V	V	V						V										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express/Savana	Body	Body Control Module																																																										
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2007	Express/Savana	Body	Passenger Presence System																																																										
G	2007	Express/Savana	Body	Base Radio																																																										
G	2007	Express/Savana	Body	Uplevel Radio																																																										
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																							V	V	V	V	V															
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								V	V	V																
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																								V	V	V						V								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																									
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																									
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																									
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																									
G	2007	Express Access/Savana Pro	Body	Radio																																																									
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																									
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V														
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V														
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V							
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																					
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
G	2008	Express/Savana	Body	Body Control Module																																																									
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																									
G	2008	Express/Savana	Body	Passenger Presence System																																																									
G	2008	Express/Savana	Body	Radio																																																									
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
G	2008	Express/Savana	Body	Rollover Sensor																																																									
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
G	2008	Express/Savana	Body	Theft Deterrent Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V														
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V														
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																									
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V							
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																									
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																					

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2008	Express Access/Savana Pro	Body	Radio																																																											
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																													V														
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																													V														
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V									
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																							
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2009	Express/Savana	Body	Body Control Module																																																											
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2009	Express/Savana	Body	Passenger Presence System																																																											
G	2009	Express/Savana	Body	Radio																																																											
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2009	Express/Savana	Body	Rollover Sensor																																																											
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2009	Express/Savana	Body	Theft Deterrent Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																													V														
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																													V														
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V								V									
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																							
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2009	Express Access/Savana Pro	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V														
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																																
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																																
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V														
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V										
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V																
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V										
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V								V								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																							
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2010	Express/Savana	Body	Body Control Module																																																											
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2010	Express/Savana	Body	Passenger Presence System																																																											
G	2010	Express/Savana	Body	Radio																																																										
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2010	Express/Savana	Body	Rollover Sensor																																																											
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2010	Express/Savana	Body	Theft Deterrent Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V														
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																																
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																																
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V														
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V										
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V																
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V										
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V									V							
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																							
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																												
G	2010	Express Access/Savana Pro	Body	Radio																																																												
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																												
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																												
H	2004	Express/Savana	Chassis	VSES																																																												
H	2004	Express/Savana	Body	Body Control Module																																																												
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																												
H	2004	Express/Savana	Body	OnStar																																																												
H	2004	Express/Savana	Body	Base Radio																																																												
H	2004	Express/Savana	Body	Uplevel Radio																																																												
H	2004	Express/Savana	Body	Remote Function Actuation																																																												
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint		V																																																										
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2004	Express Access/Savana Pro	Chassis	VSES																																																												
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2004	Express Access/Savana Pro	Body	OnStar																																																												
H	2004	Express Access/Savana Pro	Body	Base Radio																																																												
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint		V																																																										
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																												
H	2005	Express/Savana	Chassis	VSES																																																												
H	2005	Express/Savana	Body	Body Control Module																																																												
H	2005	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																												
H	2005	Express/Savana	Body	Base Radio																																																												
H	2005	Express/Savana	Body	Uplevel Radio																																																												
H	2005	Express/Savana	Body	Remote Function Actuation																																																												
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint		V																																																										
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2005	Express Access/Savana Pro	Chassis	VSES																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2005	Express Access/Savana Pro	Body	Base Radio																																																												
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint		V																																																										
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																												
H	2006	Express/Savana	Chassis	VSES																																																												
H	2006	Express/Savana	Body	Body Control Module																																																												
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																												
H	2006	Express/Savana	Body	Passenger Presence System																																																												
H	2006	Express/Savana	Body	Base Radio																																																												
H	2006	Express/Savana	Body	Uplevel Radio																																																												
H	2006	Express/Savana	Body	Remote Function Actuation																																																												
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint		V																																																										
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																												
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																												
H	2006	Express Access/Savana Pro	Chassis	VSES																																																												
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																												
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2006	Express Access/Savana Pro	Body	Base Radio																																																												
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																												
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																												
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint		V																																																										
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																												
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																											
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																											
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2007	Express/Savana	Body	Body Control Module																																																											
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																											
H	2007	Express/Savana	Body	Passenger Presence System																																																											
H	2007	Express/Savana	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2007	Express/Savana	Body	Uplevel Radio																																																										
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2007	Express Access/Savana Pro	Body	Base Radio																																																										
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																										
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																						
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2008	Express/Savana	Body	Body Control Module																																																										
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2008	Express/Savana	Body	Passenger Presence System																																																										
H	2008	Express/Savana	Body	Radio																																																										
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express/Savana	Body	Rollover Sensor																																																										
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express/Savana	Body	Theft Deterrent Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																						
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2008	Express Access/Savana Pro	Body	Radio																																																										
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																						
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express/Savana	Body	Body Control Module																																																										
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																										
H	2009	Express/Savana	Body	Passenger Presence System																																																										
H	2009	Express/Savana	Body	Radio																																																										
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express/Savana	Body	Rollover Sensor																																																										
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express/Savana	Body	Theft Deterrent Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																						
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																										
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																										
H	2009	Express Access/Savana Pro	Body	Radio																																																										
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																										
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																							
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2010	Express/Savana	Body	Body Control Module																																																											
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2010	Express/Savana	Body	Passenger Presence System																																																											
H	2010	Express/Savana	Body	Radio																																																											
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
H	2010	Express/Savana	Body	Rollover Sensor																																																											
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2010	Express/Savana	Body	Theft Deterrent Module																																																											
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																																
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																																
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																							
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																											
H	2010	Express Access/Savana Pro	Body	Radio																																																											
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																											
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																			V	V																							
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																					V																						
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																											
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																											
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																											
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																											
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																						V																						
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																							V																					
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																						V		V																					
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																							V																					
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																							V																					
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																												
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																												
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
K	2004	ALL	Chassis	ESC																																																											
K	2004	ALL	Chassis	Rear Wheel Steering																																																												
K	2004	ALL	Chassis	Tire Pressure Monitor																																																												
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																												
K	2004	ALL	Chassis	VSES																																																											
K	2004	ALL	Body	Amplifier (Bose)																																																												
K	2004	ALL	Body	Body Control Module																																																											
K	2004	ALL	Body	CD Changer																																																											
K	2004	ALL	Body	Chime																																																											
K	2004	ALL	Body	Driver Door Module																																																											
K	2004	ALL	Body	Driver Seat Module																																																											
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2004	ALL	Body	Instrument Panel Cluster																																																											
K	2004	ALL	Body	OnStar																																																										
K	2004	ALL	Body	Passenger Door Module																																																										
K	2004	ALL	Body	Passenger Presence System																																																										
K	2004	ALL	Body	Radio Base																																																										
K	2004	ALL	Body	Radio Uplevel																																																										
K	2004	ALL	Body	Radio Navigation																																																										
K	2004	ALL	Body	Rear Aux. Climate Module	V																																																										
K	2004	ALL	Body	Rear HVAC																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2004	ALL	Body	Rear Seat Audio																																																												
K	2004	ALL	Body	Rear Seat Entertainment																																																												
K	2004	ALL	Body	Supplemental Inflatable Restraint		V																																																										
K	2004	ALL	Body	Vehicle Theft Deterrent																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																			V	V																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																												
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																												
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																												
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																												
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																												
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																												
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																												
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																												
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																						V		V																					
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																							V																					
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																												
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																							V																					
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																												
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																												
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																											
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
K	2005	ALL	Chassis	ESC																																																											
K	2005	ALL	Chassis	Rear Wheel Steering																																																											
K	2005	ALL	Chassis	Tire Pressure Monitor																																																											
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																											
K	2005	ALL	Chassis	VSES																																																											
K	2005	ALL	Body	Amplifier (Bose)																																																											
K	2005	ALL	Body	Body Control Module																																																											
K	2005	ALL	Body	CD Changer																																																											
K	2005	ALL	Body	Chime																																																											
K	2005	ALL	Body	Disc Player and Video Display																																																											
K	2005	ALL	Body	Driver Door Module																																																											
K	2005	ALL	Body	Driver Seat Module																																																											
K	2005	ALL	Body	Generator Battery Control Module																																																											
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																											
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2005	ALL	Body	Instrument Panel Cluster																																																											
K	2005	ALL	Body	Passenger Door Module																																																											
K	2005	ALL	Body	Passenger Presence System																																																											
K	2005	ALL	Body	Base Radio																																																											
K	2005	ALL	Body	Uplevel Radio																																																											
K	2005	ALL	Body	Navigation Radio																																																											
K	2005	ALL	Body	Rear Aux. Climate Module	V																																																											
K	2005	ALL	Body	Rear HVAC																																																											
K	2005	ALL	Body	Rear Seat Audio																																																											
K	2005	ALL	Body	Supplemental Inflatable Restraint		V																																																									
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																											
K	2005	ALL	Body	Vehicle Theft Deterrent																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																			V	V																							
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																											
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																											
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																									
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																							V	V	V	V	V														
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																						V						V													
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																								V	V	V															
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																							V	V	V	V	V														
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																						V						V													
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								V	V	V															
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																						V						V													
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																										
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																										
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																										
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																										
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																										
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																										
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																										
K	2006	ALL	Chassis	ESC																																																									
K	2006	ALL	Chassis	Tire Pressure Monitor																																																										
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																										
K	2006	ALL	Chassis	VSES																																																									
K	2006	ALL	Body	Amplifier (Bose)																																																										
K	2006	ALL	Body	Body Control Module																																																										
K	2006	ALL	Body	CD Changer																																																										
K	2006	ALL	Body	Chime																																																										
K	2006	ALL	Body	Disc Player and Video Display																																																										
K	2006	ALL	Body	Driver Door Module																																																										
K	2006	ALL	Body	Driver Seat Module																																																										
K	2006	ALL	Body	Generator Battery Control Module																																																										
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2006	ALL	Body	Instrument Panel Cluster																																																												
K	2006	ALL	Body	Passenger Door Module																																																												
K	2006	ALL	Body	Passenger Presence System																																																												
K	2006	ALL	Body	Base Radio																																																												
K	2006	ALL	Body	Uplevel Radio																																																												
K	2006	ALL	Body	Navigation Radio																																																												
K	2006	ALL	Body	Rear Aux. Climate Module	V																																																											
K	2006	ALL	Body	Rear HVAC																																																												
K	2006	ALL	Body	Rear Seat Audio																																																												
K	2006	ALL	Body	Supplemental Inflatable Restraint			V																																																									
K	2006	ALL	Body	Vehicle Theft Deterrent																																																												
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V											
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																						V					V															
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V									
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																						
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2007	Sierra	Chassis	Electronic Suspension Control																																																										
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2007	Sierra	Body	Amplifier (Bose)																																																										
K	2007	Sierra	Body	Body Control Module																																																									
K	2007	Sierra	Body	Body Control Module (aux.)																																																									
K	2007	Sierra	Body	Digital Radio Receiver																																																									
K	2007	Sierra	Body	Driver Door Switch																																																									
K	2007	Sierra	Body	HVAC Control Module Auto						V																																								V											
K	2007	Sierra	Body	HVAC Control Module Manual						V																																																			
K	2007	Sierra	Body	Instrument Panel Cluster																																																									
K	2007	Sierra	Body	Memory Seat Module							V																																																	
K	2007	Sierra	Body	Park Assist Module								V																																															
K	2007	Sierra	Body	Passenger Door Switch																																																								
K	2007	Sierra	Body	Passenger Presence System																																																								
K	2007	Sierra	Body	Radio																																																								
K	2007	Sierra	Body	Rear Heated Seat Module																																																								
K	2007	Sierra	Body	Rear HVAC/RSA																																																								
K	2007	Sierra	Body	Rollover Sensor																																																								
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																																								
K	2007	Sierra	Body	Theft Deterrent Module																																																								
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																								
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																														V											
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																								
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																								
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																														V											
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																								
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																								
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																								
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																								
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																														V											
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																								
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																					
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES					V																																																					
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																									
K	2007	Yukon	Chassis	Electronic Suspension Control																																																								
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																								
K	2007	Yukon	Body	Amplifier (Bose)																																																								
K	2007	Yukon	Body	Assist Step Controller																																																								
K	2007	Yukon	Body	Body Control Module																																																								
K	2007	Yukon	Body	Body Control Module (aux.)																																																								
K	2007	Yukon	Body	Digital Radio Receiver																																																								
K	2007	Yukon	Body	Driver Door Switch																																																								
K	2007	Yukon	Body	HVAC Control Module Auto						V																																								V											
K	2007	Yukon	Body	HVAC Control Module Manual						V																																																			
K	2007	Yukon	Body	Instrument Panel Cluster																																																								
K	2007	Yukon	Body	Lift Gate Module																																																								
K	2007	Yukon	Body	Memory Seat Module							V																																																	
K	2007	Yukon	Body	Park Assist Module								V																																															

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2007	Yukon	Body	Passenger Door Switch																																																												
K	2007	Yukon	Body	Passenger Presence System																																																												
K	2007	Yukon	Body	Radio																																																											
K	2007	Yukon	Body	Rear Heated Seat Module																																																											
K	2007	Yukon	Body	Rear HVAC/RSA																																																											
K	2007	Yukon	Body	Rollover Sensor																																																											
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																																											
K	2007	Yukon	Body	Theft Deterrent Module																																																											
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES				V	V																																																						
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES					V																																																						
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																											
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																											
K	2007	Yukon XL	Body	Amplifier (Bose)																																																											
K	2007	Yukon XL	Body	Assist Step Controller																																																											
K	2007	Yukon XL	Body	Body Control Module																																																											
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																											
K	2007	Yukon XL	Body	Digital Radio Receiver																																																											
K	2007	Yukon XL	Body	Driver Door Switch																																																											
K	2007	Yukon XL	Body	HVAC Control Module Auto						V																																																					
K	2007	Yukon XL	Body	HVAC Control Module Manual						V																																																					
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																											
K	2007	Yukon XL	Body	Lift Gate Module																																																											
K	2007	Yukon XL	Body	Memory Seat Module							V																																																				
K	2007	Yukon XL	Body	Park Assist Module								V																																																			
K	2007	Yukon XL	Body	Passenger Door Switch																																																											
K	2007	Yukon XL	Body	Passenger Presence System																																																											
K	2007	Yukon XL	Body	Radio																																																										
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																											
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																											
K	2007	Yukon XL	Body	Rollover Sensor																																																											
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
K	2007	Yukon XL	Body	Theft Deterrent Module																																																											
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V									
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V								
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																						V						V														
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES					V																																																					
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES					V																																																					
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Sierra	Chassis	Electronic Suspension Control																																																										
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2008	Sierra	Body	Amplifier (Bose)																																																										
K	2008	Sierra	Body	Body Control Module																																																										
K	2008	Sierra	Body	Body Control Module (aux.)																																																										
K	2008	Sierra	Body	Digital Radio Receiver																																																										
K	2008	Sierra	Body	Driver Door Switch																																																										
K	2008	Sierra	Body	HVAC Control Module Auto						V																																									V											
K	2008	Sierra	Body	HVAC Control Module Manual						V																																																				
K	2008	Sierra	Body	Instrument Panel Cluster																																																										
K	2008	Sierra	Body	Memory Seat Module							V																																																			
K	2008	Sierra	Body	Park Assist Module								V																																																		
K	2008	Sierra	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2008	Sierra	Body	Passenger Presence System																																																										
K	2008	Sierra	Body	Radio																																																										
K	2008	Sierra	Body	Rear Heated Seat Module																																																										
K	2008	Sierra	Body	Rear HVAC/RSA																																																										
K	2008	Sierra	Body	Rollover Sensor																																																										
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																																										
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																										
K	2008	Sierra	Body	Theft Deterrent Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Yukon	Chassis	Electronic Brake Control Module				V																																																						
K	2008	Yukon	Chassis	Electronic Suspension Control																																																										
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																										
K	2008	Yukon	Body	Amplifier (Bose)																																																										
K	2008	Yukon	Body	Assist Step Controller																																																										
K	2008	Yukon	Body	Body Control Module																																																										
K	2008	Yukon	Body	Body Control Module (aux.)																																																										
K	2008	Yukon	Body	Digital Radio Receiver																																																										
K	2008	Yukon	Body	Driver Door Switch																																																										
K	2008	Yukon	Body	HVAC Control Module Auto						V																																										V										
K	2008	Yukon	Body	HVAC Control Module Manual						V																																																				
K	2008	Yukon	Body	Instrument Panel Cluster																																																										
K	2008	Yukon	Body	Lift Gate Module																																																										
K	2008	Yukon	Body	Memory Seat Module							V																																																			
K	2008	Yukon	Body	Park Assist Module								V																																																		
K	2008	Yukon	Body	Passenger Door Switch																																																										
K	2008	Yukon	Body	Passenger Presence System																																																										
K	2008	Yukon	Body	Radio																																																										
K	2008	Yukon	Body	Rear Heated Seat Module																																																										
K	2008	Yukon	Body	Rear HVAC/RSA																																																										
K	2008	Yukon	Body	Rollover Sensor																																																										
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																																										
K	2008	Yukon	Body	Theft Deterrent Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																V	V		V	V						
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																					V	V				
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																						V	V
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																											
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																											
K	2008	Yukon Hybrid	Body	Body Control Module																																																											
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																											
K	2008	Yukon Hybrid	Body	Driver Door Switch																																																											
K	2008	Yukon Hybrid	Body	HVAC Control Module						V																																										V				V						
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
K	2008	Yukon Hybrid	Body	Lift Gate Module																																																											
K	2008	Yukon Hybrid	Body	Memory Seat Module							V																																																				
K	2008	Yukon Hybrid	Body	Park Assist Module								V																																																			
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																																											
K	2008	Yukon Hybrid	Body	Passenger Presence System																																																											
K	2008	Yukon Hybrid	Body	Radio																																																											
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																											
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																	V										
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																	V										
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																	V										
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																	V										
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW				V																																																							

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																										
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																										
K	2008	Yukon XL	Body	Amplifier (Bose)																																																										
K	2008	Yukon XL	Body	Assist Step Controller																																																										
K	2008	Yukon XL	Body	Body Control Module																																																										
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																										
K	2008	Yukon XL	Body	Digital Radio Receiver																																																										
K	2008	Yukon XL	Body	Driver Door Switch																																																										
K	2008	Yukon XL	Body	HVAC Control Module Auto						V																																								V												
K	2008	Yukon XL	Body	HVAC Control Module Manual						V																																																				
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																										
K	2008	Yukon XL	Body	Lift Gate Module																																																										
K	2008	Yukon XL	Body	Memory Seat Module							V																																																			
K	2008	Yukon XL	Body	Park Assist Module								V																																																		
K	2008	Yukon XL	Body	Passenger Door Switch																																																										
K	2008	Yukon XL	Body	Passenger Presence System																																																										
K	2008	Yukon XL	Body	Radio																																																										
K	2008	Yukon XL	Body	Rear Heated Seat Module																																																										
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																										
K	2008	Yukon XL	Body	Rollover Sensor																																																										
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
K	2008	Yukon XL	Body	Theft Deterrent Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																														V												
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																										
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																														V												
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																														V												
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V									
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																						V							V													

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																											
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																												V														
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES					V																																																					
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES					V																																																					
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																						
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
K	2009	Sierra	Chassis	Electronic Suspension Control																																																										
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2009	Sierra	Body	Amplifier (Bose)																																																										
K	2009	Sierra	Body	Body Control Module																																																									
K	2009	Sierra	Body	Body Control Module (aux.)																																																									
K	2009	Sierra	Body	Digital Radio Receiver																																																									
K	2009	Sierra	Body	Driver Door Switch																																																									
K	2009	Sierra	Body	HVAC Control Module Auto						V																																							V												
K	2009	Sierra	Body	HVAC Control Module Manual						V																																																			
K	2009	Sierra	Body	Instrument Panel Cluster																																																									
K	2009	Sierra	Body	Memory Seat Module							V																																																	
K	2009	Sierra	Body	Park Assist Module								V																																																
K	2009	Sierra	Body	Passenger Door Switch																																																									
K	2009	Sierra	Body	Passenger Presence System																																																									
K	2009	Sierra	Body	Radio																																																								
K	2009	Sierra	Body	Rear Heated Seat Module																																																									
K	2009	Sierra	Body	Rear HVAC/RSA																																																									
K	2009	Sierra	Body	Rollover Sensor																																																								
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																																								
K	2009	Sierra	Body	Theft Deterrent Module																																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																														V	V		V	V					
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																				V	V		
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																							
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																			V	V
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																							
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																							
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																							
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																							
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																							
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																							
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																																							
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																							
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																							

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																												
K	2009	Sierra Hybrid	Body	Body Control Module																																																												
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Sierra Hybrid	Body	Driver Door Switch																																																												
K	2009	Sierra Hybrid	Body	HVAC Control Module						V																																											V				V						
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
K	2009	Sierra Hybrid	Body	Memory Seat Module							V																																																					
K	2009	Sierra Hybrid	Body	Park Assist Module								V																																																				
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																																												
K	2009	Sierra Hybrid	Body	Passenger Presence System																																																												
K	2009	Sierra Hybrid	Body	Radio																																																												
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Sierra Hybrid	Body	Rollover Sensor																																																												
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Yukon	Chassis	Electronic Brake Control Module					V																																																							
K	2009	Yukon	Chassis	Electronic Suspension Control																																																												
K	2009	Yukon	Chassis	Trailer Brake Control Module																																																												
K	2009	Yukon	Body	Amplifier (Bose)																																																												
K	2009	Yukon	Body	Assist Step Controller																																																												
K	2009	Yukon	Body	Body Control Module																																																											
K	2009	Yukon	Body	Body Control Module (aux.)																																																											
K	2009	Yukon	Body	Digital Radio Receiver																																																											
K	2009	Yukon	Body	Driver Door Switch																																																											
K	2009	Yukon	Body	HVAC Control Module Auto						V																																											V										
K	2009	Yukon	Body	HVAC Control Module Manual						V																																																					

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2009	Yukon	Body	Instrument Panel Cluster																																																												
K	2009	Yukon	Body	Left Side Object Detection Module																																																												
K	2009	Yukon	Body	Lift Gate Module																																																												
K	2009	Yukon	Body	Memory Seat Module							V																																																				
K	2009	Yukon	Body	Park Assist Module								V																																																			
K	2009	Yukon	Body	Passenger Door Switch																																																												
K	2009	Yukon	Body	Passenger Presence System																																																												
K	2009	Yukon	Body	Radio																																																											
K	2009	Yukon	Body	Rear Heated Seat Module																																																												
K	2009	Yukon	Body	Rear HVAC/RSA																																																												
K	2009	Yukon	Body	Right Side Object Detection Module																																																												
K	2009	Yukon	Body	Rollover Sensor																																																												
K	2009	Yukon	Body	Supplemental Inflatable Restraint																																																												
K	2009	Yukon	Body	Theft Deterrent Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																V	V		V	V				
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																					V	V			
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																			V																						V	V
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																																												
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																												
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																												
K	2009	Yukon Hybrid	Body	Body Control Module																																																												
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Yukon Hybrid	Body	Driver Door Switch																																																												
K	2009	Yukon Hybrid	Body	Heated Seat Module																																																												
K	2009	Yukon Hybrid	Body	HVAC Control Module						V																																										V			V					
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
K	2009	Yukon Hybrid	Body	Park Assist Module								V																																																			
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																																												
K	2009	Yukon Hybrid	Body	Passenger Presence System																																																												
K	2009	Yukon Hybrid	Body	Radio																																																												
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
K	2009	Yukon Hybrid	Body	Rollover Sensor																																																												
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																												
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW					V																																																							
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																												
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																												
K	2009	Yukon XL	Body	Amplifier (Bose)																																																												
K	2009	Yukon XL	Body	Assist Step Controller																																																												
K	2009	Yukon XL	Body	Body Control Module																																																												
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																												
K	2009	Yukon XL	Body	Digital Radio Receiver																																																												
K	2009	Yukon XL	Body	Driver Door Switch																																																												
K	2009	Yukon XL	Body	HVAC Control Module Auto						V																																																					
K	2009	Yukon XL	Body	HVAC Control Module Manual						V																																																					
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																											
K	2009	Yukon XL	Body	Left Side Object Detection Module																																																											
K	2009	Yukon XL	Body	Lift Gate Module																																																											
K	2009	Yukon XL	Body	Memory Seat Module							V																																																			
K	2009	Yukon XL	Body	Park Assist Module								V																																																		
K	2009	Yukon XL	Body	Passenger Door Switch																																																											
K	2009	Yukon XL	Body	Passenger Presence System																																																											
K	2009	Yukon XL	Body	Radio																																																										
K	2009	Yukon XL	Body	Rear Heated Seat Module																																																											
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																											
K	2009	Yukon XL	Body	Right Side Object Detection Module																																																											
K	2009	Yukon XL	Body	Rollover Sensor																																																											
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
K	2009	Yukon XL	Body	Theft Deterrent Module																																																											
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																											
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																	
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module											V	V																																																
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								V	V	V	V				V	V										
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								V	V	V							V									
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																						V					V															
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																																
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES					V																																																							
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES					V																																																							
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2010	Sierra	Chassis	Electronic Suspension Control																																																												
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																												
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra	Body	Amplifier (Bose)																																																												
K	2010	Sierra	Body	Body Control Module																																																											
K	2010	Sierra	Body	Body Control Module (aux.)																																																											
K	2010	Sierra	Body	Digital Radio Receiver																																																											
K	2010	Sierra	Body	Driver Door Switch																																																											
K	2010	Sierra	Body	HVAC Control Module Auto						V																																										V										
K	2010	Sierra	Body	HVAC Control Module Manual						V																																																					
K	2010	Sierra	Body	Instrument Panel Cluster																																																											
K	2010	Sierra	Body	Memory Seat Module							V																																																				
K	2010	Sierra	Body	Park Assist Module																																																											
K	2010	Sierra	Body	Passenger Door Switch																																																											
K	2010	Sierra	Body	Passenger Presence System																																																											
K	2010	Sierra	Body	Radio																																																										
K	2010	Sierra	Body	Rear Heated Seat Module																																																											
K	2010	Sierra	Body	Rear HVAC/RSA																																																											
K	2010	Sierra	Body	Supplemental Inflatable Restraint																																																											
K	2010	Sierra	Body	Theft Deterrent Module																																																											
K	2010	Sierra Hybrid	Powertrain	Engine Control Module																																															V	V		V	V						
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																					V	V		
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																							
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																		V																				V	V
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																						
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																						
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																						
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																						
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																						
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																						
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																						
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																						
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																																						
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																						
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																						
K	2010	Sierra Hybrid	Body	Body Control Module																																																						
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																						
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																						
K	2010	Sierra Hybrid	Body	Driver Door Switch																																																						
K	2010	Sierra Hybrid	Body	Heated Seat Module																																																						
K	2010	Sierra Hybrid	Body	HVAC Control Module						V																																												V						
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																						
K	2010	Sierra Hybrid	Body	Park Assist Module																																																						
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																																						
K	2010	Sierra Hybrid	Body	Passenger Presence System																																																						
K	2010	Sierra Hybrid	Body	Radio																																																						
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																						
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																						
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																						
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																						
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																						
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																						
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																						
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																						
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																						
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																						
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																						
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																						
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																						
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																						
K	2010	Yukon	Chassis	Electronic Brake Control Module					V																																																	
K	2010	Yukon	Chassis	Electronic Suspension Control																																																						
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																						
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																						
K	2010	Yukon	Body	Amplifier (Bose)																																																					
K	2010	Yukon	Body	Assist Step Controller																																																					
K	2010	Yukon	Body	Body Control Module																																																					
K	2010	Yukon	Body	Body Control Module (aux.)																																																					
K	2010	Yukon	Body	Digital Radio Receiver																																																					
K	2010	Yukon	Body	Driver Door Switch																																																					
K	2010	Yukon	Body	HVAC Control Module Auto						V																																						V										
K	2010	Yukon	Body	HVAC Control Module Manual						V																																															

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2010	Yukon	Body	Instrument Panel Cluster																																																												
K	2010	Yukon	Body	Left Side Object Detection Module																																																												
K	2010	Yukon	Body	Lift Gate Module																																																												
K	2010	Yukon	Body	Memory Seat Module							V																																																				
K	2010	Yukon	Body	Park Assist Module																																																											
K	2010	Yukon	Body	Passenger Door Switch																																																											
K	2010	Yukon	Body	Passenger Presence System																																																											
K	2010	Yukon	Body	Radio																																																											
K	2010	Yukon	Body	Rear Heated Seat Module																																																											
K	2010	Yukon	Body	Rear HVAC/RSA																																																											
K	2010	Yukon	Body	Right Side Object Detection Module																																																											
K	2010	Yukon	Body	Supplemental Inflatable Restraint																																																											
K	2010	Yukon	Body	Theft Deterrent Module																																																											
K	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																V	V		V	V				
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																					V	V			
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																		V																						V	V
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																										
K	2010	Yukon Hybrid	Body	Body Control Module																																																										
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																										
K	2010	Yukon Hybrid	Body	Driver Door Switch																																																										
K	2010	Yukon Hybrid	Body	Heated Seat Module																																																										
K	2010	Yukon Hybrid	Body	HVAC Control Module						V																																													V							
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
K	2010	Yukon Hybrid	Body	Lift Gate Module																																																										
K	2010	Yukon Hybrid	Body	Park Assist Module																																																										
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																																										
K	2010	Yukon Hybrid	Body	Passenger Presence System																																																										
K	2010	Yukon Hybrid	Body	Radio																																																										
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																										
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																															
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																	
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW					V																																																							
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																												
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																												
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																												
K	2010	Yukon XL	Body	Amplifier (Bose)																																																												
K	2010	Yukon XL	Body	Assist Step Controller																																																												
K	2010	Yukon XL	Body	Body Control Module																																																												
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																												
K	2010	Yukon XL	Body	Digital Radio Receiver																																																												
K	2010	Yukon XL	Body	Driver Door Switch																																																												
K	2010	Yukon XL	Body	HVAC Control Module Auto						V																																												V										
K	2010	Yukon XL	Body	HVAC Control Module Manual						V																																																					
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																												
K	2010	Yukon XL	Body	Left Side Object Detection Module																																																												
K	2010	Yukon XL	Body	Lift Gate Module																																																												
K	2010	Yukon XL	Body	Memory Seat Module							V																																																					
K	2010	Yukon XL	Body	Park Assist Module																																																												
K	2010	Yukon XL	Body	Passenger Door Switch																																																												
K	2010	Yukon XL	Body	Passenger Presence System																																																												
K	2010	Yukon XL	Body	Radio																																																												
K	2010	Yukon XL	Body	Rear Heated Seat Module																																																												
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																												
K	2010	Yukon XL	Body	Right Side Object Detection Module																																																												
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
K	2010	Yukon XL	Body	Theft Deterrent Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
L	2004	ALL	Chassis	4WAL 3 Sensor																																																												
L	2004	ALL	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2004	ALL	Body	Instrument Panel Cluster																																																												
L	2004	ALL	Body	Supplemental Inflatable Restraint		V																																																										
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
L	2005	ALL	Chassis	4WAL 3 Sensor																																																												
L	2005	ALL	Body	Body Control Module																																																											
L	2005	ALL	Body	Instrument Panel Cluster																																																											
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																											
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																											
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																											
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																											
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																											
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2010	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2010	Terrain	Body	Body Control Module																																																											
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2010	Terrain	Body	Passenger Presence Module																																																											
L	2010	Terrain	Body	Instrument Cluster																																																											
L	2010	Terrain	Body	Radio																																																											
L	2010	Terrain	Body	Multimedia Player Interface Module																																																											
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																																											
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2010	Terrain	Body	Liftgate Control Module																																																											
L	2010	Terrain	Body	Parking Assist Control Module																																																											
L	2010	Terrain	Body	Frontview Camera Module																																																											
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																																											
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																																											
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																											
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																											
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																											
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																											
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2011	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2011	Terrain	Body	Body Control Module																																																											
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2011	Terrain	Body	Passenger Presence Module																																																											
L	2011	Terrain	Body	Instrument Cluster																																																											
L	2011	Terrain	Body	Radio																																																											
L	2011	Terrain	Body	Multimedia Player Interface Module																																																											
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																											
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2011	Terrain	Body	Liftgate Control Module																																																												
L	2011	Terrain	Body	Parking Assist Control Module																																																												
L	2011	Terrain	Body	Frontview Camera Module																																																												
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																												
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2012	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2012	Terrain	Body	Body Control Module																																																												
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2012	Terrain	Body	Passenger Presence Module																																																												
L	2012	Terrain	Body	Instrument Cluster																																																												
L	2012	Terrain	Body	Radio																																																												
L	2012	Terrain	Body	Multimedia Player Interface Module																																																												
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2012	Terrain	Body	Liftgate Control Module																																																												
L	2012	Terrain	Body	Parking Assist Control Module																																																												
L	2012	Terrain	Body	Frontview Camera Module																																																												
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																																												
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2013	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2013	Terrain	Chassis	Power Steering Control Module																																																												
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																																												
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2013	Terrain	Body	Passenger Presence Module																																																												
L	2013	Terrain	Body	Instrument Cluster																																																												
L	2013	Terrain	Body	Radio																																																												
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2013	Terrain	Body	Liftgate Control Module																																																												
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																												
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																												
L	2013	Terrain	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2013	Terrain	Body	Frontview Camera Module																																																												
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2014	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2014	Terrain	Chassis	Power Steering Control Module																																																												
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																																												
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2014	Terrain	Body	Passenger Presence Module																																																												
L	2014	Terrain	Body	Instrument Cluster																																																												
L	2014	Terrain	Body	Radio																																																												
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2014	Terrain	Body	Liftgate Control Module																																																												
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																												
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																												
L	2014	Terrain	Body	Parking Assist Control Module																																																												
L	2014	Terrain	Body	Frontview Camera Module																																																												
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2015	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2015	Terrain	Chassis	Power Steering Control Module																																																												
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																																												
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2015	Terrain	Body	Passenger Presence Module																																																												
L	2015	Terrain	Body	Instrument Cluster																																																												
L	2015	Terrain	Body	Radio																																																											
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																																												
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2015	Terrain	Body	Liftgate Control Module																																																												
L	2015	Terrain	Body	Seat Memory Control Module																																																												
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																												
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																												
L	2015	Terrain	Body	Parking Assist Control Module																																																												
L	2015	Terrain	Body	Frontview Camera Module																																																												
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																											
L	2016	Terrain	Chassis	Electronic Brake Control Module																																																											
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																											
L	2016	Terrain	Chassis	Power Steering Control Module																																																											
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																											
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																																											
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																											
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
L	2016	Terrain	Body	Passenger Presence Module																																																											
L	2016	Terrain	Body	Instrument Cluster																																																											
L	2016	Terrain	Body	Radio																																																											
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																																											
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																											
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																																											
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2016	Terrain	Body	Liftgate Control Module																																																											
L	2016	Terrain	Body	Seat Memory Control Module																																																											
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																											
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																											
L	2016	Terrain	Body	Parking Assist Control Module																																																											
L	2016	Terrain	Body	Frontview Camera Module																																																											
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
M	2004	ALL	Chassis	4WAL 3 Sensor																																																											
M	2004	ALL	Body	Body Control Module																																																										
M	2004	ALL	Body	Instrument Panel Cluster																																																											
M	2004	ALL	Body	Supplemental Inflatable Restraint		V																																																									
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
M	2005	ALL	Chassis	4WAL 3 Sensor																																																											
M	2005	ALL	Body	Body Control Module																																																										
M	2005	ALL	Body	Instrument Panel Cluster																																																											
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																											
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																											
P	2007	ALL	Body	Supplemental Inflatable Restraint			V																																																								
P	2007	ALL	Body	Theft Deterrent Module																																																											
R	2007	ALL	Powertrain	Engine Control Module																																																											
R	2007	ALL	Powertrain	Transmission Control Module																																																											
R	2007	ALL	Chassis	Electronic Brake Control Module					V																																																						
R	2007	ALL	Body	Body Control Module																																																										
R	2007	ALL	Body	Digital Radio Receiver																																																											
R	2007	ALL	Body	Driver Door Switch																																																											
R	2007	ALL	Body	Head Up Display																																																										
R	2007	ALL	Body	Heated Seat Module																																																											
R	2007	ALL	Body	HVAC Control Module Auto						V																																																					
R	2007	ALL	Body	HVAC Control Module Manual						V																																																					
R	2007	ALL	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
R	2007	ALL	Body	Lift Gate Module																																																											
R	2007	ALL	Body	Park Assist Module								V																																																		
R	2007	ALL	Body	Passenger Door Switch																																																										
R	2007	ALL	Body	Passenger Presence System																																																										
R	2007	ALL	Body	Radio																																																										
R	2007	ALL	Body	Rear HVAC/RSA																																																										
R	2007	ALL	Body	Rollover Sensor																																																										
R	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2007	ALL	Body	Theft Deterrent Module																																																										
R	2008	ALL	Powertrain	Engine Control Module																																																										
R	2008	ALL	Powertrain	Transmission Control Module																																																										
R	2008	ALL	Chassis	Electronic Brake Control Module					V																																																					
R	2008	ALL	Body	Body Control Module																																																										
R	2008	ALL	Body	Digital Radio Receiver																																																										
R	2008	ALL	Body	Driver Door Switch																																																										
R	2008	ALL	Body	Head Up Display																																																										
R	2008	ALL	Body	Heated Seat Module																																																										
R	2008	ALL	Body	HVAC Control Module Auto						V																																																				
R	2008	ALL	Body	HVAC Control Module Manual						V																																																				
R	2008	ALL	Body	Instrument Panel Cluster																																																										
R	2008	ALL	Body	Lift Gate Module																																																										
R	2008	ALL	Body	Park Assist Module								V																																																	
R	2008	ALL	Body	Passenger Door Switch																																																										
R	2008	ALL	Body	Passenger Presence System																																																										
R	2008	ALL	Body	Radio																																																										
R	2008	ALL	Body	Rear HVAC/RSA																																																										
R	2008	ALL	Body	Rollover Sensor																																																										
R	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2008	ALL	Body	Theft Deterrent Module																																																										
R	2009	ALL	Powertrain	Engine Control Module																																																										
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																										
R	2009	ALL	Powertrain	Transmission Control Module																																																										
R	2009	ALL	Chassis	Electronic Brake Control Module					V																																																					
R	2009	ALL	Body	Body Control Module																																																										
R	2009	ALL	Body	Digital Radio Receiver																																																										
R	2009	ALL	Body	Driver Door Switch																																																										
R	2009	ALL	Body	Head Up Display																																																										
R	2009	ALL	Body	Heated Seat Module																																																										
R	2009	ALL	Body	HVAC Control Module Auto						V																																																				
R	2009	ALL	Body	HVAC Control Module Manual						V																																																				
R	2009	ALL	Body	Instrument Panel Cluster																																																										
R	2009	ALL	Body	Lift Gate Module																																																										
R	2009	ALL	Body	Park Assist Module								V																																																	
R	2009	ALL	Body	Passenger Door Switch																																																										
R	2009	ALL	Body	Passenger Presence System																																																										
R	2009	ALL	Body	Radio																																																										
R	2009	ALL	Body	Rear HVAC/RSA																																																										
R	2009	ALL	Body	Rollover Sensor																																																										
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																										
R	2009	ALL	Body	Theft Deterrent Module																																																										
R	2010	ALL	Powertrain	Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2010	ALL	Powertrain	Transmission Control Module																																																												
R	2010	ALL	Chassis	Electronic Brake Control Module					V																																																							
R	2010	ALL	Body	Body Control Module																																																											
R	2010	ALL	Body	Digital Radio Receiver																																																											
R	2010	ALL	Body	Driver Door Switch																																																											
R	2010	ALL	Body	Head Up Display																																																											
R	2010	ALL	Body	Heated Seat Module																																																											
R	2010	ALL	Body	HVAC Control Module Auto						V																																												V										
R	2010	ALL	Body	HVAC Control Module Manual						V																																																					
R	2010	ALL	Body	Instrument Panel Cluster																																																											
R	2010	ALL	Body	Lift Gate Module																																																											
R	2010	ALL	Body	Park Assist Module																																																											
R	2010	ALL	Body	Passenger Door Switch																																																											
R	2010	ALL	Body	Passenger Presence System																																																											
R	2010	ALL	Body	Radio																																																											
R	2010	ALL	Body	Rear HVAC/RSA																																																											
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2010	ALL	Body	Theft Deterrent Module																																																											
R	2011	ALL	Powertrain	Engine Control Module																																																											
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2011	ALL	Powertrain	Transmission Control Module																																																											
R	2011	ALL	Chassis	Electronic Brake Control Module					V																																																						
R	2011	ALL	Body	Body Control Module																																																											
R	2011	ALL	Body	Digital Radio Receiver																																																											
R	2011	ALL	Body	Driver Door Switch																																																											
R	2011	ALL	Body	Head Up Display																																																											
R	2011	ALL	Body	Heated Seat Module																																																											
R	2011	ALL	Body	HVAC Control Module Auto						V																																												V										
R	2011	ALL	Body	HVAC Control Module Manual						V																																																					
R	2011	ALL	Body	Instrument Panel Cluster																																																											
R	2011	ALL	Body	Lift Gate Module																																																											
R	2011	ALL	Body	Park Assist Module																																																											
R	2011	ALL	Body	Passenger Door Switch																																																											
R	2011	ALL	Body	Passenger Presence System																																																											
R	2011	ALL	Body	Radio																																																											
R	2011	ALL	Body	Rear HVAC/RSA																																																											
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
R	2011	ALL	Body	Theft Deterrent Module																																																											
R	2012	ALL	Powertrain	Engine Control Module																																																											
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																											
R	2012	ALL	Powertrain	Transmission Control Module																																																											
R	2012	ALL	Chassis	Electronic Brake Control Module					V																																																						
R	2012	ALL	Body	Body Control Module																																																											
R	2012	ALL	Body	Digital Radio Receiver																																																											
R	2012	ALL	Body	Driver Door Switch																																																											
R	2012	ALL	Body	Head Up Display																																																											
R	2012	ALL	Body	Heated Seat Module																																																											
R	2012	ALL	Body	HVAC Control Module Auto						V																																												V										
R	2012	ALL	Body	HVAC Control Module Manual						V																																																					
R	2012	ALL	Body	Instrument Panel Cluster																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
R	2012	ALL	Body	Lift Gate Module																																																												
R	2012	ALL	Body	Park Assist Module																																																												
R	2012	ALL	Body	Passenger Door Switch																																																												
R	2012	ALL	Body	Passenger Presence System																																																												
R	2012	ALL	Body	Radio																																																												
R	2012	ALL	Body	Rear HVAC/RSA																																																												
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2012	ALL	Body	Theft Deterrent Module																																																												
R	2013	ALL	Powertrain	Engine Control Module																																																												
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2013	ALL	Powertrain	Transmission Control Module																																																												
R	2013	ALL	Chassis	Electronic Brake Control Module					V																																																							
R	2013	ALL	Body	Body Control Module																																																												
R	2013	ALL	Body	Digital Radio Receiver																																																												
R	2013	ALL	Body	Driver Door Switch																																																												
R	2013	ALL	Body	Head Up Display																																																												
R	2013	ALL	Body	Heated Seat Module																																																												
R	2013	ALL	Body	HVAC Control Module Auto						V																																												V										
R	2013	ALL	Body	HVAC Control Module Manual						V																																																						
R	2013	ALL	Body	Instrument Panel Cluster																																																												
R	2013	ALL	Body	Left Side Object Detection Module																																																												
R	2013	ALL	Body	Lift Gate Module																																																												
R	2013	ALL	Body	Park Assist Module																																																												
R	2013	ALL	Body	Passenger Door Switch																																																												
R	2013	ALL	Body	Passenger Presence System																																																												
R	2013	ALL	Body	Radio																																																												
R	2013	ALL	Body	Rear HVAC/RSA																																																												
R	2013	ALL	Body	Right Side Object Detection Module																																																												
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2013	ALL	Body	Theft Deterrent Module																																																												
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2014	Acadia	Powertrain	Chassis Control Module																																																												
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
R	2014	Acadia	Chassis	Electronic Brake Control Module																																																												
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Acadia	Body	Passenger Presence Module																																																												
R	2014	Acadia	Body	Instrument Cluster																																																												
R	2014	Acadia	Body	Head-Up Display Module																																																												
R	2014	Acadia	Body	Radio																																																												
R	2014	Acadia	Body	Rear Audio Control Module																																																												
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																												
R	2014	Acadia	Body	Personal Audio Link Control Module																																																												
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																											
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																											
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
R	2014	Acadia	Body	Liftgate Control Module																																																												
R	2014	Acadia	Body	Seat Memory Control Module																																																												
R	2014	Acadia	Body	Front Seat Heating Control Module																																																												
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																												
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																												
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																												
R	2014	Acadia	Body	Parking Assist Control Module																																																												
R	2014	Acadia	Body	Frontview Camera Module																																																												
R	2014	Acadia	Body	Theft Deterrent Module																																																												
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
R	2015	Acadia	Chassis	Electronic Brake Control Module																																																												
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2015	Acadia	Body	Passenger Presence Module																																																												
R	2015	Acadia	Body	Instrument Cluster																																																												
R	2015	Acadia	Body	Head-Up Display Module																																																												
R	2015	Acadia	Body	Radio																																																												
R	2015	Acadia	Body	Rear Audio Control Module																																																												
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																												
R	2015	Acadia	Body	Personal Audio Link Control Module																																																												
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																												
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																												
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																												
R	2015	Acadia	Body	Liftgate Control Module																																																												
R	2015	Acadia	Body	Seat Memory Control Module																																																												
R	2015	Acadia	Body	Front Seat Heating Control Module																																																												
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																												
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																												
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																												
R	2015	Acadia	Body	Parking Assist Control Module																																																												
R	2015	Acadia	Body	Frontview Camera Module																																																												
R	2015	Acadia	Body	Theft Deterrent Module																																																												
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
R	2016	Acadia	Chassis	Electronic Brake Control Module																																																												
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2016	Acadia	Body	Passenger Presence Module																																																												
R	2016	Acadia	Body	Instrument Cluster																																																												
R	2016	Acadia	Body	Head-Up Display Module																																																												
R	2016	Acadia	Body	Radio																																																											
R	2016	Acadia	Body	Rear Audio Control Module																																																												
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
R	2016	Acadia	Body	Personal Audio Link Control Module																																																											
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																											
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																											
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																											
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																											
R	2016	Acadia	Body	Liftgate Control Module																																																											
R	2016	Acadia	Body	Seat Memory Control Module																																																											
R	2016	Acadia	Body	Front Seat Heating Control Module																																																											
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																											
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																											
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																											
R	2016	Acadia	Body	Parking Assist Control Module																																																											
R	2016	Acadia	Body	Frontview Camera Module																																																											
R	2016	Acadia	Body	Theft Deterrent Module																																																											
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																											
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Sonoma	Body	Body Control Module																																																											
S	2004	Sonoma	Body	Instrument Panel Cluster																																																											
S	2004	Sonoma	Body	Base Radio																																																											
S	2004	Sonoma	Body	Uplevel Radio																																																											
S	2004	Sonoma	Body	Supplemental Inflatable Restraint		V																																																									
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2004	Canyon	Chassis	ABS Without Traction Control																																																											
S	2004	Canyon	Chassis	ABS With Traction Control																																																											
S	2004	Canyon	Body	Body Control Module																																																											
S	2004	Canyon	Body	Instrument Panel Cluster																																																											
S	2004	Canyon	Body	OnStar																																																											
S	2004	Canyon	Body	Base Radio																																																											
S	2004	Canyon	Body	Uplevel Radio																																																											
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2004	Envoy	Chassis	ABS Without Traction Control																																																											
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Envoy	Body	Amplifier (Bose)																																																											
S	2004	Envoy	Body	Body Control Module																																																											
S	2004	Envoy	Body	Driver Door Module																																																											
S	2004	Envoy	Body	Driver Seat Module																																																											
S	2004	Envoy	Body	Heating and Air Conditioning Auto																																																											
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																											
S	2004	Envoy	Body	Instrument Panel Cluster																																																											
S	2004	Envoy	Body	Lift Gate Module																																																											
S	2004	Envoy	Body	OnStar																																																											
S	2004	Envoy	Body	Passenger Door Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2004	Envoy	Body	Uplevel Radio																																																											
S	2004	Envoy	Body	Navigation Radio																																																											
S	2004	Envoy	Body	Rear Seat Audio																																																											
S	2004	Envoy	Body	Rear Seat Entertainment																																																											
S	2004	Envoy	Body	Supplemental Inflatable Restraint		V																																																									
S	2004	Envoy	Body	Vehicle Theft Deterrent																																																											
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																											
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																											
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																											
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Envoy XL	Body	Amplifier (Bose)																																																											
S	2004	Envoy XL	Body	Body Control Module																																																											
S	2004	Envoy XL	Body	Driver Door Module																																																											
S	2004	Envoy XL	Body	Driver Seat Module																																																											
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																											
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																											
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																											
S	2004	Envoy XL	Body	Lift Gate Module																																																											
S	2004	Envoy XL	Body	OnStar																																																											
S	2004	Envoy XL	Body	Passenger Door Module																																																											
S	2004	Envoy XL	Body	Uplevel Radio																																																											
S	2004	Envoy XL	Body	Navigation Radio																																																											
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																											
S	2004	Envoy XL	Body	Rear HVAC Manual																																																											
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																											
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint		V																																																									
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																											
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																											
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																											
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																											
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																											
S	2004	Envoy XUV	Body	Body Control Module																																																											
S	2004	Envoy XUV	Body	Driver Door Module																																																											
S	2004	Envoy XUV	Body	Driver Seat Module																																																											
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																											
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																											
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																											
S	2004	Envoy XUV	Body	Lift Gate Module																																																											
S	2004	Envoy XUV	Body	OnStar																																																											
S	2004	Envoy XUV	Body	Passenger Door Module																																																											
S	2004	Envoy XUV	Body	Uplevel Radio																																																											
S	2004	Envoy XUV	Body	Navigation Radio																																																											
S	2004	Envoy XUV	Body	Rear Seat Audio																																																											
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint		V																																																									
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																											
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																												
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																												
S	2004	Jimmy	Body	Body Control Module																																																												
S	2004	Jimmy	Body	Heating and Air Conditioning																																																												
S	2004	Jimmy	Body	Instrument Panel Cluster																																																												
S	2004	Jimmy	Body	Memory Seat Module																																																												
S	2004	Jimmy	Body	Base Radio																																																												
S	2004	Jimmy	Body	Uplevel Radio																																																												
S	2004	Jimmy	Body	Supplemental Inflatable Restraint		V																																																										
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
S	2005	Canyon	Chassis	ABS Without Traction Control																																																												
S	2005	Canyon	Chassis	ABS With Traction Control																																																												
S	2005	Canyon	Body	Body Control Module																																																												
S	2005	Canyon	Body	Instrument Panel Cluster																																																												
S	2005	Canyon	Body	Base Radio																																																												
S	2005	Canyon	Body	Uplevel Radio																																																												
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																																												
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																																												
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2005	Envoy	Chassis	ABS Without Traction Control																																																												
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																												
S	2005	Envoy	Body	Body Control Module																																																												
S	2005	Envoy	Body	Disc Player and Video Display																																																												
S	2005	Envoy	Body	Driver Door Module																																																												
S	2005	Envoy	Body	Driver Seat Module																																																												
S	2005	Envoy	Body	Heating and Air Conditioning Auto																																																												
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																																												
S	2005	Envoy	Body	Instrument Panel Cluster																																																												
S	2005	Envoy	Body	Lift Gate Module																																																												
S	2005	Envoy	Body	Passenger Door Module																																																												
S	2005	Envoy	Body	Passenger Presence System																																																												
S	2005	Envoy	Body	Uplevel Radio																																																												
S	2005	Envoy	Body	Navigation Radio																																																												
S	2005	Envoy	Body	Rear Seat Audio																																																												
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																																												
S	2005	Envoy	Body	Vehicle Theft Deterrent																																																												
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																												
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																												
S	2005	Envoy XL	Body	Body Control Module																																																												
S	2005	Envoy XL	Body	Disc Player and Video Display																																																												
S	2005	Envoy XL	Body	Driver Door Module																																																												
S	2005	Envoy XL	Body	Driver Seat Module																																																												
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
S	2005	Envoy XL	Body	Instrument Panel Cluster																																																												
S	2005	Envoy XL	Body	Lift Gate Module																																																												
S	2005	Envoy XL	Body	Passenger Door Module																																																												
S	2005	Envoy XL	Body	Passenger Presence System																																																												
S	2005	Envoy XL	Body	Uplevel Radio																																																												
S	2005	Envoy XL	Body	Navigation Radio																																																												
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
S	2005	Envoy XL	Body	Rear HVAC Manual																																																												
S	2005	Envoy XL	Body	Rear Seat Audio																																																												
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																												
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																												
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																												
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																												
S	2005	Envoy XUV	Body	Body Control Module																																																												
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																												
S	2005	Envoy XUV	Body	Driver Door Module																																																												
S	2005	Envoy XUV	Body	Driver Seat Module																																																												
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																												
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																												
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																																												
S	2005	Envoy XUV	Body	Lift Gate Module																																																												
S	2005	Envoy XUV	Body	Passenger Door Module																																																												
S	2005	Envoy XUV	Body	Passenger Presence System																																																												
S	2005	Envoy XUV	Body	Uplevel Radio																																																												
S	2005	Envoy XUV	Body	Navigation Radio																																																												
S	2005	Envoy XUV	Body	Rear Seat Audio																																																												
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																												
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																												
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																												
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																												
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																												
S	2005	Jimmy	Body	Body Control Module																																																												
S	2005	Jimmy	Body	Heating and Air Conditioning																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2005	Jimmy	Body	Instrument Panel Cluster																																																											
S	2005	Jimmy	Body	Memory Seat Module																																																											
S	2005	Jimmy	Body	Base Radio																																																										
S	2005	Jimmy	Body	Uplevel Radio																																																										
S	2005	Jimmy	Body	Supplemental Inflatable Restraint		V																																																								
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																										
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																										
S	2005	Sonoma	Body	Body Control Module																																																										
S	2005	Sonoma	Body	Instrument Panel Cluster																																																										
S	2005	Sonoma	Body	Base Radio																																																										
S	2005	Sonoma	Body	Uplevel Radio																																																										
S	2005	Sonoma	Body	Supplemental Inflatable Restraint		V																																																								
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																										
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																										
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																										
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																										
S	2006	Canyon	Chassis	ABS Without Traction Control																																																										
S	2006	Canyon	Chassis	ABS With Traction Control																																																										
S	2006	Canyon	Body	Body Control Module																																																										
S	2006	Canyon	Body	Instrument Panel Cluster																																																										
S	2006	Canyon	Body	Passenger Presence System																																																										
S	2006	Canyon	Body	Base Radio																																																										
S	2006	Canyon	Body	Uplevel Radio																																																										
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																																										
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2006	Envoy	Chassis	ABS/TCS/VSES																																																										
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																										
S	2006	Envoy	Body	Body Control Module																																																										
S	2006	Envoy	Body	Disc Player and Video Display																																																										
S	2006	Envoy	Body	Driver Door Module																																																										
S	2006	Envoy	Body	Driver Seat Module																																																										
S	2006	Envoy	Body	Heating and Air Conditioning Auto																																																										
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																																										
S	2006	Envoy	Body	Instrument Panel Cluster																																																										
S	2006	Envoy	Body	Lift Gate Module																																																										
S	2006	Envoy	Body	Passenger Door Module																																																										
S	2006	Envoy	Body	Passenger Presence System																																																										
S	2006	Envoy	Body	Uplevel Radio																																																										
S	2006	Envoy	Body	Navigation Radio																																																										
S	2006	Envoy	Body	Rear Seat Audio																																																										
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2006	Envoy	Body	Vehicle Theft Deterrent																																																										
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																									
S	2006	Envoy XL	Body	Body Control Module																																																									
S	2006	Envoy XL	Body	Disc Player and Video Display																																																									
S	2006	Envoy XL	Body	Driver Door Module																																																									
S	2006	Envoy XL	Body	Driver Seat Module																																																									
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																									
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																									
S	2006	Envoy XL	Body	Instrument Panel Cluster																																																									
S	2006	Envoy XL	Body	Lift Gate Module																																																									
S	2006	Envoy XL	Body	Passenger Door Module																																																									
S	2006	Envoy XL	Body	Passenger Presence System																																																									
S	2006	Envoy XL	Body	Uplevel Radio																																																									
S	2006	Envoy XL	Body	Navigation Radio																																																									
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																									
S	2006	Envoy XL	Body	Rear HVAC Manual																																																									
S	2006	Envoy XL	Body	Rear Seat Audio																																																									
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																									
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																									
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																									
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																									
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																									
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																									
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																									
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																									
S	2007	Canyon	Body	Body Control Module																																																									
S	2007	Canyon	Body	Digital Radio Receiver																																																									
S	2007	Canyon	Body	Generator Battery Control Module																																																									
S	2007	Canyon	Body	Instrument Panel Cluster																																																									
S	2007	Canyon	Body	Passenger Presence System																																																									
S	2007	Canyon	Body	Base Radio																																																									
S	2007	Canyon	Body	Uplevel Radio																																																									
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																																									
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																																									
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																									
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																									
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																									
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																									
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																									
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																									
S	2007	Envoy	Chassis	Electronic Brake Control Module																																																									
S	2007	Envoy	Body	Body Control Module																																																									
S	2007	Envoy	Body	Digital Radio Receiver																																																									
S	2007	Envoy	Body	Disc Player and Video Display																																																									
S	2007	Envoy	Body	Driver Door Module																																																									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2007	Envoy	Body	Driver Seat Module																																																												
S	2007	Envoy	Body	Generator Battery Control Module																																																												
S	2007	Envoy	Body	HVAC Control Module Auto																																																												
S	2007	Envoy	Body	HVAC Control Module Manual																																																												
S	2007	Envoy	Body	Instrument Panel Cluster																																																												
S	2007	Envoy	Body	Lift Gate Module																																																												
S	2007	Envoy	Body	Passenger Door Module																																																												
S	2007	Envoy	Body	Passenger Presence System																																																												
S	2007	Envoy	Body	Uplevel Radio																																																												
S	2007	Envoy	Body	Navigation Radio																																																												
S	2007	Envoy	Body	Rear Seat Audio																																																												
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2007	Envoy	Body	Theft Deterrent Module																																																												
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																																												
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2008	Canyon	Body	Body Control Module																																																												
S	2008	Canyon	Body	Digital Radio Receiver																																																												
S	2008	Canyon	Body	Generator Battery Control Module																																																												
S	2008	Canyon	Body	Instrument Panel Cluster																																																												
S	2008	Canyon	Body	Passenger Presence System																																																												
S	2008	Canyon	Body	Base Radio																																																												
S	2008	Canyon	Body	Uplevel Radio																																																												
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																																												
S	2008	Canyon	Body	Theft Deterrent Module																																																												
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																																												
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
S	2008	Envoy	Chassis	Electronic Brake Control Module																																																												
S	2008	Envoy	Body	Body Control Module																																																												
S	2008	Envoy	Body	Digital Radio Receiver																																																												
S	2008	Envoy	Body	Disc Player and Video Display																																																												
S	2008	Envoy	Body	Driver Door Module																																																												
S	2008	Envoy	Body	Driver Seat Module																																																												
S	2008	Envoy	Body	Generator Battery Control Module																																																												
S	2008	Envoy	Body	HVAC Control Module Auto																																																												
S	2008	Envoy	Body	HVAC Control Module Manual																																																												
S	2008	Envoy	Body	Instrument Panel Cluster																																																												
S	2008	Envoy	Body	Lift Gate Module																																																												
S	2008	Envoy	Body	Passenger Door Module																																																												
S	2008	Envoy	Body	Passenger Presence System																																																												
S	2008	Envoy	Body	Uplevel Radio																																																												
S	2008	Envoy	Body	Navigation Radio																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2008	Envoy	Body	Rear Seat Audio																																																												
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2008	Envoy	Body	Theft Deterrent Module																																																												
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																																												
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																												
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																												
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																												
S	2009	Canyon	Chassis	Electronic Brake Control Module																																																												
S	2009	Canyon	Body	Body Control Module																																																												
S	2009	Canyon	Body	Digital Radio Receiver																																																												
S	2009	Canyon	Body	Generator Battery Control Module																																																												
S	2009	Canyon	Body	Instrument Panel Cluster																																																												
S	2009	Canyon	Body	Passenger Presence System																																																												
S	2009	Canyon	Body	Base Radio																																																											
S	2009	Canyon	Body	Uplevel Radio																																																											
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2009	Canyon	Body	Theft Deterrent Module																																																											
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																											
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																											
S	2009	Envoy	Chassis	Electronic Brake Control Module																																																												
S	2009	Envoy	Body	Body Control Module																																																												
S	2009	Envoy	Body	Digital Radio Receiver																																																												
S	2009	Envoy	Body	Disc Player and Video Display																																																												
S	2009	Envoy	Body	Driver Door Module																																																												
S	2009	Envoy	Body	Driver Seat Module																																																												
S	2009	Envoy	Body	Generator Battery Control Module																																																												
S	2009	Envoy	Body	HVAC Control Module Auto																																																												
S	2009	Envoy	Body	HVAC Control Module Manual																																																												
S	2009	Envoy	Body	Instrument Panel Cluster																																																												
S	2009	Envoy	Body	Lift Gate Module																																																												
S	2009	Envoy	Body	Passenger Door Module																																																												
S	2009	Envoy	Body	Passenger Presence System																																																												
S	2009	Envoy	Body	Uplevel Radio																																																												
S	2009	Envoy	Body	Navigation Radio																																																												
S	2009	Envoy	Body	Rear Seat Audio																																																												
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2009	Envoy	Body	Theft Deterrent Module																																																												
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																													V												
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																									
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																									
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																													V												
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																									
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																									
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																													V												
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																									
S	2010	ALL	Chassis	Electronic Brake Control Module																																																										
S	2010	ALL	Body	Body Control Module																																																									
S	2010	ALL	Body	Digital Radio Receiver																																																									
S	2010	ALL	Body	Generator Battery Control Module																																																									
S	2010	ALL	Body	Instument Panel Cluster																																																									
S	2010	ALL	Body	Passenger Presence System																																																									
S	2010	ALL	Body	Personal Audio Link Module																																																									
S	2010	ALL	Body	Base Radio																																																									
S	2010	ALL	Body	Uplevel Radio																																																									
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																									
S	2010	ALL	Body	Theft Deterrent Module																																																									
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																									
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																									
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																									
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Sonoma	Body	Body Control Module																																																									
T	2004	Sonoma	Body	Instrument Panel Cluster																																																									
T	2004	Sonoma	Body	Base Radio																																																									
T	2004	Sonoma	Body	Uplevel Radio																																																									
T	2004	Sonoma	Body	Supplemental Inflatable Restraint		V																																																							
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																									
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																									
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																									
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																									
T	2004	Canyon	Chassis	ABS Without Traction Control																																																									
T	2004	Canyon	Chassis	ABS With Traction Control																																																									
T	2004	Canyon	Body	Body Control Module																																																									
T	2004	Canyon	Body	Instrument Panel Cluster																																																									
T	2004	Canyon	Body	OnStar																																																									
T	2004	Canyon	Body	Base Radio																																																									
T	2004	Canyon	Body	Uplevel Radio																																																									
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																																									
T	2004	Canyon	Body	Instrument Panel Cluster																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																									
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																									
T	2004	Envoy	Chassis	ABS Without Traction Control																																																									
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																									
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																									
T	2004	Envoy	Body	Amplifier (Bose)																																																									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2004	Envoy	Body	Body Control Module																																																											
T	2004	Envoy	Body	Driver Door Module																																																											
T	2004	Envoy	Body	Driver Seat Module																																																											
T	2004	Envoy	Body	Heating and Air Conditioning Auto																																																											
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																																											
T	2004	Envoy	Body	Instrument Panel Cluster																																																											
T	2004	Envoy	Body	Lift Gate Module																																																											
T	2004	Envoy	Body	OnStar																																																											
T	2004	Envoy	Body	Passenger Door Module																																																											
T	2004	Envoy	Body	Uplevel Radio																																																											
T	2004	Envoy	Body	Navigation Radio																																																											
T	2004	Envoy	Body	Rear Seat Audio																																																											
T	2004	Envoy	Body	Rear Seat Entertainment																																																											
T	2004	Envoy	Body	Supplemental Inflatable Restraint		V																																																									
T	2004	Envoy	Body	Vehicle Theft Deterrent																																																											
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																											
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																											
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																											
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																											
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																											
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																											
T	2004	Envoy XL	Body	Amplifier (Bose)																																																											
T	2004	Envoy XL	Body	Body Control Module																																																											
T	2004	Envoy XL	Body	Driver Door Module																																																											
T	2004	Envoy XL	Body	Driver Seat Module																																																											
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																											
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																											
T	2004	Envoy XL	Body	Instrument Panel Cluster																																																											
T	2004	Envoy XL	Body	Lift Gate Module																																																											
T	2004	Envoy XL	Body	OnStar																																																											
T	2004	Envoy XL	Body	Passenger Door Module																																																											
T	2004	Envoy XL	Body	Uplevel Radio																																																											
T	2004	Envoy XL	Body	Navigation Radio																																																											
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																											
T	2004	Envoy XL	Body	Rear HVAC Manual																																																											
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																											
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint		V																																																									
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																											
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																											
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																											
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																											
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																											
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																											
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																											
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2004	Envoy XUV	Body	Body Control Module																																																												
T	2004	Envoy XUV	Body	Driver Door Module																																																												
T	2004	Envoy XUV	Body	Driver Seat Module																																																												
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																												
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																												
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																																												
T	2004	Envoy XUV	Body	Lift Gate Module																																																												
T	2004	Envoy XUV	Body	OnStar																																																												
T	2004	Envoy XUV	Body	Passenger Door Module																																																												
T	2004	Envoy XUV	Body	Uplevel Radio																																																												
T	2004	Envoy XUV	Body	Navigation Radio																																																												
T	2004	Envoy XUV	Body	Rear Seat Audio																																																												
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																												
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint		V																																																									
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																											
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																												
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																												
T	2004	Jimmy	Body	Body Control Module																																																												
T	2004	Jimmy	Body	Heating and Air Conditioning																																																												
T	2004	Jimmy	Body	Instrument Panel Cluster																																																												
T	2004	Jimmy	Body	Memory Seat Module																																																												
T	2004	Jimmy	Body	Base Radio																																																												
T	2004	Jimmy	Body	Uplevel Radio																																																												
T	2004	Jimmy	Body	Supplemental Inflatable Restraint		V																																																									
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2005	Canyon	Chassis	ABS Without Traction Control																																																												
T	2005	Canyon	Chassis	ABS With Traction Control																																																												
T	2005	Canyon	Body	Body Control Module																																																												
T	2005	Canyon	Body	Instrument Panel Cluster																																																												
T	2005	Canyon	Body	Base Radio																																																												
T	2005	Canyon	Body	Uplevel Radio																																																												
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																											
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																											
T	2005	Envoy	Chassis	ABS Without Traction Control																																																												
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Envoy	Body	Body Control Module																																																												
T	2005	Envoy	Body	Disc Player and Video Display																																																												
T	2005	Envoy	Body	Driver Door Module																																																												
T	2005	Envoy	Body	Driver Seat Module																																																												
T	2005	Envoy	Body	Heating and Air Conditioning Auto																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																																											
T	2005	Envoy	Body	Instrument Panel Cluster																																																												
T	2005	Envoy	Body	Lift Gate Module																																																												
T	2005	Envoy	Body	Passenger Door Module																																																												
T	2005	Envoy	Body	Passenger Presence System																																																												
T	2005	Envoy	Body	Uplevel Radio																																																												
T	2005	Envoy	Body	Navigation Radio																																																												
T	2005	Envoy	Body	Rear Seat Audio																																																												
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																																												
T	2005	Envoy	Body	Vehicle Theft Deterrent																																																												
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																												
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Envoy XL	Body	Body Control Module																																																												
T	2005	Envoy XL	Body	Disc Player and Video Display																																																												
T	2005	Envoy XL	Body	Driver Door Module																																																												
T	2005	Envoy XL	Body	Driver Seat Module																																																												
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
T	2005	Envoy XL	Body	Instrument Panel Cluster																																																												
T	2005	Envoy XL	Body	Lift Gate Module																																																												
T	2005	Envoy XL	Body	Passenger Door Module																																																												
T	2005	Envoy XL	Body	Passenger Presence System																																																												
T	2005	Envoy XL	Body	Uplevel Radio																																																												
T	2005	Envoy XL	Body	Navigation Radio																																																												
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
T	2005	Envoy XL	Body	Rear HVAC Manual																																																												
T	2005	Envoy XL	Body	Rear Seat Audio																																																												
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																												
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																												
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																												
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Envoy XUV	Body	Body Control Module																																																												
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																												
T	2005	Envoy XUV	Body	Driver Door Module																																																												
T	2005	Envoy XUV	Body	Driver Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																											
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																											
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																																											
T	2005	Envoy XUV	Body	Lift Gate Module																																																											
T	2005	Envoy XUV	Body	Passenger Door Module																																																											
T	2005	Envoy XUV	Body	Passenger Presence System																																																											
T	2005	Envoy XUV	Body	Uplevel Radio																																																											
T	2005	Envoy XUV	Body	Navigation Radio																																																											
T	2005	Envoy XUV	Body	Rear Seat Audio																																																											
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																											
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																											
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																											
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																											
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																											
T	2005	Jimmy	Body	Body Control Module																																																											
T	2005	Jimmy	Body	Heating and Air Conditioning																																																											
T	2005	Jimmy	Body	Instrument Panel Cluster																																																											
T	2005	Jimmy	Body	Memory Seat Module																																																											
T	2005	Jimmy	Body	Base Radio																																																											
T	2005	Jimmy	Body	Uplevel Radio																																																											
T	2005	Jimmy	Body	Supplemental Inflatable Restraint		V																																																									
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																											
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																											
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																											
T	2005	Sonoma	Body	Body Control Module																																																											
T	2005	Sonoma	Body	Instrument Panel Cluster																																																											
T	2005	Sonoma	Body	Base Radio																																																											
T	2005	Sonoma	Body	Uplevel Radio																																																											
T	2005	Sonoma	Body	Supplemental Inflatable Restraint		V																																																									
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
T	2006	Canyon	Chassis	ABS Without Traction Control																																																											
T	2006	Canyon	Chassis	ABS With Traction Control																																																											
T	2006	Canyon	Body	Body Control Module																																																											
T	2006	Canyon	Body	Instrument Panel Cluster																																																											
T	2006	Canyon	Body	Passenger Presence System																																																											
T	2006	Canyon	Body	Base Radio																																																											
T	2006	Canyon	Body	Uplevel Radio																																																											
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																																											
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																																											
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																											
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2006	Envoy	Chassis	ABS/TCS/VSES																																																												
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																												
T	2006	Envoy	Body	Body Control Module																																																												
T	2006	Envoy	Body	Disc Player and Video Display																																																												
T	2006	Envoy	Body	Driver Door Module																																																												
T	2006	Envoy	Body	Driver Seat Module																																																												
T	2006	Envoy	Body	Heating and Air Conditioning Auto																																																												
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																																												
T	2006	Envoy	Body	Instrument Panel Cluster																																																												
T	2006	Envoy	Body	Lift Gate Module																																																												
T	2006	Envoy	Body	Passenger Door Module																																																												
T	2006	Envoy	Body	Passenger Presence System																																																												
T	2006	Envoy	Body	Uplevel Radio																																																												
T	2006	Envoy	Body	Navigation Radio																																																												
T	2006	Envoy	Body	Rear Seat Audio																																																												
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2006	Envoy	Body	Vehicle Theft Deterrent																																																												
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																																												
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																												
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																												
T	2006	Envoy XL	Body	Body Control Module																																																												
T	2006	Envoy XL	Body	Disc Player and Video Display																																																												
T	2006	Envoy XL	Body	Driver Door Module																																																												
T	2006	Envoy XL	Body	Driver Seat Module																																																												
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
T	2006	Envoy XL	Body	Instrument Panel Cluster																																																												
T	2006	Envoy XL	Body	Lift Gate Module																																																												
T	2006	Envoy XL	Body	Passenger Door Module																																																												
T	2006	Envoy XL	Body	Passenger Presence System																																																												
T	2006	Envoy XL	Body	Uplevel Radio																																																												
T	2006	Envoy XL	Body	Navigation Radio																																																												
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
T	2006	Envoy XL	Body	Rear HVAC Manual																																																												
T	2006	Envoy XL	Body	Rear Seat Audio																																																												
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																												
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																												
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																												
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																												
T	2007	Canyon	Body	Body Control Module																																																												
T	2007	Canyon	Body	Digital Radio Receiver																																																												
T	2007	Canyon	Body	Generator Battery Control Module																																																												
T	2007	Canyon	Body	Instrument Panel Cluster																																																												
T	2007	Canyon	Body	Passenger Presence System																																																												
T	2007	Canyon	Body	Base Radio																																																												
T	2007	Canyon	Body	Uplevel Radio																																																												
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																												
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																												
T	2007	Envoy	Chassis	Electronic Brake Control Module																																																												
T	2007	Envoy	Body	Body Control Module																																																												
T	2007	Envoy	Body	Digital Radio Receiver																																																												
T	2007	Envoy	Body	Disc Player and Video Display																																																												
T	2007	Envoy	Body	Driver Door Module																																																												
T	2007	Envoy	Body	Driver Seat Module																																																												
T	2007	Envoy	Body	Generator Battery Control Module																																																												
T	2007	Envoy	Body	HVAC Control Module Auto																																																												
T	2007	Envoy	Body	HVAC Control Module Manual																																																												
T	2007	Envoy	Body	Instrument Panel Cluster																																																												
T	2007	Envoy	Body	Lift Gate Module																																																												
T	2007	Envoy	Body	Passenger Door Module																																																												
T	2007	Envoy	Body	Passenger Presence System																																																												
T	2007	Envoy	Body	Uplevel Radio																																																												
T	2007	Envoy	Body	Navigation Radio																																																												
T	2007	Envoy	Body	Rear Seat Audio																																																												
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2007	Envoy	Body	Theft Deterrent Module																																																												
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																																												
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2008	Canyon	Body	Body Control Module																																																										
T	2008	Canyon	Body	Digital Radio Receiver																																																										
T	2008	Canyon	Body	Generator Battery Control Module																																																										
T	2008	Canyon	Body	Instrument Panel Cluster																																																										
T	2008	Canyon	Body	Passenger Presence System																																																										
T	2008	Canyon	Body	Base Radio																																																										
T	2008	Canyon	Body	Uplevel Radio																																																										
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																																										
T	2008	Canyon	Body	Theft Deterrent Module																																																										
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
T	2008	Envoy	Chassis	Electronic Brake Control Module																																																										
T	2008	Envoy	Body	Body Control Module																																																										
T	2008	Envoy	Body	Digital Radio Receiver																																																										
T	2008	Envoy	Body	Disc Player and Video Display																																																										
T	2008	Envoy	Body	Driver Door Module																																																										
T	2008	Envoy	Body	Driver Seat Module																																																										
T	2008	Envoy	Body	Generator Battery Control Module																																																										
T	2008	Envoy	Body	HVAC Control Module Auto																																																										
T	2008	Envoy	Body	HVAC Control Module Manual																																																										
T	2008	Envoy	Body	Instrument Panel Cluster																																																										
T	2008	Envoy	Body	Lift Gate Module																																																										
T	2008	Envoy	Body	Passenger Door Module																																																										
T	2008	Envoy	Body	Passenger Presence System																																																										
T	2008	Envoy	Body	Uplevel Radio																																																										
T	2008	Envoy	Body	Navigation Radio																																																										
T	2008	Envoy	Body	Rear Seat Audio																																																										
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																																										
T	2008	Envoy	Body	Theft Deterrent Module																																																										
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																										
T	2009	Canyon	Chassis	Electronic Brake Control Module																																																										
T	2009	Canyon	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2009	Canyon	Body	Digital Radio Receiver																																																												
T	2009	Canyon	Body	Generator Battery Control Module																																																												
T	2009	Canyon	Body	Instrument Panel Cluster																																																												
T	2009	Canyon	Body	Passenger Presence System																																																												
T	2009	Canyon	Body	Base Radio																																																												
T	2009	Canyon	Body	Uplevel Radio																																																												
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2009	Canyon	Body	Theft Deterrent Module																																																												
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																												
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																												
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																												
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																													
T	2009	Envoy	Body	Body Control Module																																																												
T	2009	Envoy	Body	Digital Radio Receiver																																																												
T	2009	Envoy	Body	Disc Player and Video Display																																																												
T	2009	Envoy	Body	Driver Door Module																																																												
T	2009	Envoy	Body	Driver Seat Module																																																												
T	2009	Envoy	Body	Generator Battery Control Module																																																												
T	2009	Envoy	Body	HVAC Control Module Auto																																																												
T	2009	Envoy	Body	HVAC Control Module Manual																																																												
T	2009	Envoy	Body	Instrument Panel Cluster																																																												
T	2009	Envoy	Body	Lift Gate Module																																																												
T	2009	Envoy	Body	Passenger Door Module																																																												
T	2009	Envoy	Body	Passenger Presence System																																																												
T	2009	Envoy	Body	Uplevel Radio																																																												
T	2009	Envoy	Body	Navigation Radio																																																												
T	2009	Envoy	Body	Rear Seat Audio																																																												
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2009	Envoy	Body	Theft Deterrent Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																												
T	2010	ALL	Chassis	Electronic Brake Control Module																																																												
T	2010	ALL	Body	Body Control Module																																																												
T	2010	ALL	Body	Digital Radio Receiver																																																												
T	2010	ALL	Body	Generator Battery Control Module																																																												
T	2010	ALL	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
T	2010	ALL	Body	Passenger Presence System																																																											
T	2010	ALL	Body	Personal Audio Link Module																																																											
T	2010	ALL	Body	Base Radio																																																										
T	2010	ALL	Body	Uplevel Radio																																																										
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																										
T	2010	ALL	Body	Theft Deterrent Module																																																										
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																										
V	2007	ALL	Powertrain	Engine Control Module																																																										
V	2007	ALL	Powertrain	Rear Drive System																																																										
V	2007	ALL	Powertrain	Transmission Control Module																																																										
V	2007	ALL	Chassis	Electronic Brake Control Module					V																																																					
V	2007	ALL	Body	Body Control Module																																																										
V	2007	ALL	Body	Digital Radio Receiver																																																										
V	2007	ALL	Body	Driver Door Switch																																																										
V	2007	ALL	Body	Head Up Display																																																										
V	2007	ALL	Body	Heated Seat Module																																																										
V	2007	ALL	Body	HVAC Control Module Auto						V																																																				
V	2007	ALL	Body	HVAC Control Module Manual						V																																																				
V	2007	ALL	Body	Instrument Panel Cluster																																																										
V	2007	ALL	Body	Lift Gate Module																																																										
V	2007	ALL	Body	Park Assist Module								V																																																	
V	2007	ALL	Body	Passenger Door Switch																																																										
V	2007	ALL	Body	Passenger Presence System																																																										
V	2007	ALL	Body	Radio																																																										
V	2007	ALL	Body	Rear HVAC/RSA																																																										
V	2007	ALL	Body	Rollover Sensor																																																										
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2007	ALL	Body	Theft Deterrent Module																																																										
V	2008	ALL	Powertrain	Engine Control Module																																																										
V	2008	ALL	Powertrain	Rear Drive System																																																										
V	2008	ALL	Powertrain	Transmission Control Module																																																										
V	2008	ALL	Chassis	Electronic Brake Control Module					V																																																					
V	2008	ALL	Body	Body Control Module																																																										
V	2008	ALL	Body	Digital Radio Receiver																																																										
V	2008	ALL	Body	Driver Door Switch																																																										
V	2008	ALL	Body	Head Up Display																																																										
V	2008	ALL	Body	Heated Seat Module																																																										
V	2008	ALL	Body	HVAC Control Module Auto						V																																																				
V	2008	ALL	Body	HVAC Control Module Manual						V																																																				
V	2008	ALL	Body	Instrument Panel Cluster																																																										
V	2008	ALL	Body	Lift Gate Module																																																										
V	2008	ALL	Body	Park Assist Module								V																																																	
V	2008	ALL	Body	Passenger Door Switch																																																										
V	2008	ALL	Body	Passenger Presence System																																																										
V	2008	ALL	Body	Radio																																																										
V	2008	ALL	Body	Rear HVAC/RSA																																																										
V	2008	ALL	Body	Rollover Sensor																																																										
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2008	ALL	Body	Theft Deterrent Module																																																										
V	2009	ALL	Powertrain	Engine Control Module																																																										
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
V	2009	ALL	Powertrain	Rear Drive System																																																														
V	2009	ALL	Powertrain	Transmission Control Module																																																														
V	2009	ALL	Chassis	Electronic Brake Control Module					V																																																									
V	2009	ALL	Body	Body Control Module																																																														
V	2009	ALL	Body	Digital Radio Receiver																																																														
V	2009	ALL	Body	Driver Door Switch																																																														
V	2009	ALL	Body	Head Up Display																																																														
V	2009	ALL	Body	Heated Seat Module																																																														
V	2009	ALL	Body	HVAC Control Module Auto						V																																																								
V	2009	ALL	Body	HVAC Control Module Manual						V																																																								
V	2009	ALL	Body	Instrument Panel Cluster																																																														
V	2009	ALL	Body	Lift Gate Module																																																														
V	2009	ALL	Body	Park Assist Module								V																																																					
V	2009	ALL	Body	Passenger Door Switch																																																														
V	2009	ALL	Body	Passenger Presence System																																																														
V	2009	ALL	Body	Radio																																																														
V	2009	ALL	Body	Rear HVAC/RSA																																																														
V	2009	ALL	Body	Rollover Sensor																																																														
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2009	ALL	Body	Theft Deterrent Module																																																														
V	2010	ALL	Powertrain	Engine Control Module																																																															
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																														
V	2010	ALL	Powertrain	Rear Drive System																																																														
V	2010	ALL	Powertrain	Transmission Control Module																																																														
V	2010	ALL	Chassis	Electronic Brake Control Module					V																																																									
V	2010	ALL	Body	Body Control Module																																																														
V	2010	ALL	Body	Digital Radio Receiver																																																														
V	2010	ALL	Body	Driver Door Switch																																																														
V	2010	ALL	Body	Head Up Display																																																														
V	2010	ALL	Body	Heated Seat Module																																																														
V	2010	ALL	Body	HVAC Control Module Auto						V																																																								
V	2010	ALL	Body	HVAC Control Module Manual						V																																																								
V	2010	ALL	Body	Instrument Panel Cluster																																																														
V	2010	ALL	Body	Lift Gate Module																																																														
V	2010	ALL	Body	Park Assist Module																																																														
V	2010	ALL	Body	Passenger Door Switch																																																														
V	2010	ALL	Body	Passenger Presence System																																																														
V	2010	ALL	Body	Radio																																																														
V	2010	ALL	Body	Rear HVAC/RSA																																																														
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2010	ALL	Body	Theft Deterrent Module																																																														
V	2011	ALL	Powertrain	Engine Control Module																																																															
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																														
V	2011	ALL	Powertrain	Rear Drive System																																																														
V	2011	ALL	Powertrain	Transmission Control Module																																																														
V	2011	ALL	Chassis	Electronic Brake Control Module					V																																																									
V	2011	ALL	Body	Body Control Module																																																														
V	2011	ALL	Body	Digital Radio Receiver																																																														
V	2011	ALL	Body	Driver Door Switch																																																														
V	2011	ALL	Body	Head Up Display																																																														
V	2011	ALL	Body	Heated Seat Module																																																														

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
V	2011	ALL	Body	HVAC Control Module Auto						V																																									V											
V	2011	ALL	Body	HVAC Control Module Manual						V																																																				
V	2011	ALL	Body	Instrument Panel Cluster																																																										
V	2011	ALL	Body	Lift Gate Module																																																										
V	2011	ALL	Body	Park Assist Module																																																										
V	2011	ALL	Body	Passenger Door Switch																																																										
V	2011	ALL	Body	Passenger Presence System																																																										
V	2011	ALL	Body	Radio																																																										
V	2011	ALL	Body	Rear HVAC/RSA																																																										
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2011	ALL	Body	Theft Deterrent Module																																																										
V	2012	ALL	Powertrain	Engine Control Module																																																										
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2012	ALL	Powertrain	Rear Drive System																																																										
V	2012	ALL	Powertrain	Transmission Control Module																																																										
V	2012	ALL	Chassis	Electronic Brake Control Module					V																																																					
V	2012	ALL	Body	Body Control Module																																																										
V	2012	ALL	Body	Digital Radio Receiver																																																										
V	2012	ALL	Body	Driver Door Switch																																																										
V	2012	ALL	Body	Head Up Display																																																										
V	2012	ALL	Body	Heated Seat Module																																																										
V	2012	ALL	Body	HVAC Control Module Auto						V																																											V											
V	2012	ALL	Body	HVAC Control Module Manual						V																																																					
V	2012	ALL	Body	Instrument Panel Cluster																																																										
V	2012	ALL	Body	Lift Gate Module																																																										
V	2012	ALL	Body	Park Assist Module																																																										
V	2012	ALL	Body	Passenger Door Switch																																																										
V	2012	ALL	Body	Passenger Presence System																																																										
V	2012	ALL	Body	Radio																																																										
V	2012	ALL	Body	Rear HVAC/RSA																																																										
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
V	2012	ALL	Body	Theft Deterrent Module																																																										
V	2013	ALL	Powertrain	Engine Control Module																																																										
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																										
V	2013	ALL	Powertrain	Rear Drive System																																																										
V	2013	ALL	Powertrain	Transmission Control Module																																																										
V	2013	ALL	Chassis	Electronic Brake Control Module					V																																																					
V	2013	ALL	Body	Body Control Module																																																										
V	2013	ALL	Body	Digital Radio Receiver																																																										
V	2013	ALL	Body	Driver Door Switch																																																										
V	2013	ALL	Body	Head Up Display																																																										
V	2013	ALL	Body	Heated Seat Module																																																										
V	2013	ALL	Body	HVAC Control Module Auto						V																																											V											
V	2013	ALL	Body	HVAC Control Module Manual						V																																																					
V	2013	ALL	Body	Instrument Panel Cluster																																																										
V	2013	ALL	Body	Left Side Object Detection Module																																																										
V	2013	ALL	Body	Lift Gate Module																																																										
V	2013	ALL	Body	Park Assist Module																																																										
V	2013	ALL	Body	Passenger Door Switch																																																										
V	2013	ALL	Body	Passenger Presence System																																																										
V	2013	ALL	Body	Radio																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
V	2013	ALL	Body	Rear HVAC/RSA																																																												
V	2013	ALL	Body	Right Side Object Detection Module																																																												
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2013	ALL	Body	Theft Deterrent Module																																																												
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2014	Acadia	Powertrain	Chassis Control Module																																																												
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
V	2014	Acadia	Chassis	Electronic Brake Control Module																																																												
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2014	Acadia	Body	Passenger Presence Module																																																												
V	2014	Acadia	Body	Instrument Cluster																																																												
V	2014	Acadia	Body	Head-Up Display Module																																																												
V	2014	Acadia	Body	Radio																																																											
V	2014	Acadia	Body	Rear Audio Control Module																																																												
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																												
V	2014	Acadia	Body	Personal Audio Link Control Module																																																												
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																												
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																												
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																												
V	2014	Acadia	Body	Liftgate Control Module																																																												
V	2014	Acadia	Body	Seat Memory Control Module																																																												
V	2014	Acadia	Body	Front Seat Heating Control Module																																																												
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																												
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																												
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																												
V	2014	Acadia	Body	Parking Assist Control Module																																																												
V	2014	Acadia	Body	Frontview Camera Module																																																												
V	2014	Acadia	Body	Theft Deterrent Module																																																												
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
V	2015	Acadia	Chassis	Electronic Brake Control Module																																																												
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2015	Acadia	Body	Passenger Presence Module																																																												
V	2015	Acadia	Body	Instrument Cluster																																																												
V	2015	Acadia	Body	Head-Up Display Module																																																												
V	2015	Acadia	Body	Radio																																																											
V	2015	Acadia	Body	Rear Audio Control Module																																																												
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																												
V	2015	Acadia	Body	Personal Audio Link Control Module																																																												
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																											
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																											
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																											
V	2015	Acadia	Body	Liftgate Control Module																																																											
V	2015	Acadia	Body	Seat Memory Control Module																																																											
V	2015	Acadia	Body	Front Seat Heating Control Module																																																											
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																											
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																											
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																											
V	2015	Acadia	Body	Parking Assist Control Module																																																											
V	2015	Acadia	Body	Frontview Camera Module																																																											
V	2015	Acadia	Body	Theft Deterrent Module																																																											
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																											
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																											
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																											
V	2016	Acadia	Chassis	Electronic Brake Control Module																																																											
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																											
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																											
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
V	2016	Acadia	Body	Passenger Presence Module																																																											
V	2016	Acadia	Body	Instrument Cluster																																																											
V	2016	Acadia	Body	Head-Up Display Module																																																											
V	2016	Acadia	Body	Radio																																																											
V	2016	Acadia	Body	Rear Audio Control Module																																																											
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																											
V	2016	Acadia	Body	Personal Audio Link Control Module																																																											
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																											
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																											
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																											
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																											
V	2016	Acadia	Body	Liftgate Control Module																																																											
V	2016	Acadia	Body	Seat Memory Control Module																																																											
V	2016	Acadia	Body	Front Seat Heating Control Module																																																											
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																											
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																											
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																											
V	2016	Acadia	Body	Parking Assist Control Module																																																											
V	2016	Acadia	Body	Frontview Camera Module																																																											
V	2016	Acadia	Body	Theft Deterrent Module																																																											
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module											V	V																																														
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																															
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																														
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V										
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V																
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																											
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																						V					V																
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V	V	V	V				V	V										
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								V	V	V																
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																											
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																						V					V																
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES					V																																																						
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES					V																																																						
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																							
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
1	2011	Sierra	Chassis	Electronic Suspension Control																																																											
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																											
1	2011	Sierra	Body	Amplifier (Bose)																																																											
1	2011	Sierra	Body	Body Control Module																																																											
1	2011	Sierra	Body	Body Control Module (aux.)																																																											
1	2011	Sierra	Body	Digital Radio Receiver																																																											
1	2011	Sierra	Body	Driver Door Switch																																																											
1	2011	Sierra	Body	HVAC Control Module Auto						V																																								V											
1	2011	Sierra	Body	HVAC Control Module Manual						V																																																					
1	2011	Sierra	Body	Instrument Panel Cluster																																																											
1	2011	Sierra	Body	Memory Seat Module							V																																																				
1	2011	Sierra	Body	Park Assist Module																																																											
1	2011	Sierra	Body	Passenger Door Switch																																																											
1	2011	Sierra	Body	Passenger Presence System																																																											
1	2011	Sierra	Body	Radio																																																											
1	2011	Sierra	Body	Rear Heated Seat Module																																																											
1	2011	Sierra	Body	Rear HVAC/RSA																																																											
1	2011	Sierra	Body	Supplemental Inflatable Restraint																																																											
1	2011	Sierra	Body	Theft Deterrent Module																																																											
1	2011	Sierra Hybrid	Powertrain	Engine Control Module																																													V	V		V	V						
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																											
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																						V	V			
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																											
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																			V																					V	V
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																											
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																											
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																											
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																											
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																											
1	2011	Sierra Hybrid	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																											
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																											
1	2011	Sierra Hybrid	Body	Driver Door Switch																																																											
1	2011	Sierra Hybrid	Body	Heated Seat Module																																																											
1	2011	Sierra Hybrid	Body	HVAC Control Module						V																																													V							
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																											
1	2011	Sierra Hybrid	Body	Park Assist Module																																																											
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																																											
1	2011	Sierra Hybrid	Body	Passenger Presence System																																																											
1	2011	Sierra Hybrid	Body	Radio																																																											
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																											
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																											
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																											
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																											
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																											
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																																
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
1	2011	Yukon	Chassis	Electronic Brake Control Module					V																																																						
1	2011	Yukon	Chassis	Electronic Suspension Control																																																											
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																											
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
1	2011	Yukon	Body	Amplifier (Bose)																																																											
1	2011	Yukon	Body	Assist Step Controller																																																											
1	2011	Yukon	Body	Body Control Module																																																											
1	2011	Yukon	Body	Body Control Module (aux.)																																																											
1	2011	Yukon	Body	Digital Radio Receiver																																																											
1	2011	Yukon	Body	Driver Door Switch																																																											
1	2011	Yukon	Body	HVAC Control Module Auto						V																																											V									
1	2011	Yukon	Body	HVAC Control Module Manual						V																																																					
1	2011	Yukon	Body	Instrument Panel Cluster																																																											
1	2011	Yukon	Body	Left Side Object Detection Module																																																											
1	2011	Yukon	Body	Lift Gate Module																																																											
1	2011	Yukon	Body	Memory Seat Module							V																																																				
1	2011	Yukon	Body	Park Assist Module																																																											
1	2011	Yukon	Body	Passenger Door Switch																																																											
1	2011	Yukon	Body	Passenger Presence System																																																											
1	2011	Yukon	Body	Radio																																																										
1	2011	Yukon	Body	Rear Heated Seat Module																																																											
1	2011	Yukon	Body	Rear HVAC/RSA																																																											
1	2011	Yukon	Body	Right Side Object Detection Module																																																											
1	2011	Yukon	Body	Supplemental Inflatable Restraint																																																											
1	2011	Yukon	Body	Theft Deterrent Module																																																											
1	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																	V	V		V	V				
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																						V	V			
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																			V																					V	V

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2011	Yukon Hybrid	Body	Body Control Module																																																										
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																										
1	2011	Yukon Hybrid	Body	HVAC Control Module						V																																														V						
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
1	2011	Yukon Hybrid	Body	Lift Gate Module																																																										
1	2011	Yukon Hybrid	Body	Park Assist Module																																																										
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2011	Yukon Hybrid	Body	Passenger Presence System																																																										
1	2011	Yukon Hybrid	Body	Radio																																																										
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																															
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module											V	V																																														
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																															
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW					V																																																					
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW				V																																																						
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																										
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon XL	Body	Amplifier (Bose)																																																										
1	2011	Yukon XL	Body	Assist Step Controller																																																										
1	2011	Yukon XL	Body	Body Control Module																																																										
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2011	Yukon XL	Body	Digital Radio Receiver																																																										
1	2011	Yukon XL	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2011	Yukon XL	Body	HVAC Control Module Auto						V																																										V										
1	2011	Yukon XL	Body	HVAC Control Module Manual						V																																																				
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																										
1	2011	Yukon XL	Body	Left Side Object Detection Module																																																										
1	2011	Yukon XL	Body	Lift Gate Module																																																										
1	2011	Yukon XL	Body	Memory Seat Module							V																																																			
1	2011	Yukon XL	Body	Park Assist Module																																																										
1	2011	Yukon XL	Body	Passenger Door Switch																																																										
1	2011	Yukon XL	Body	Passenger Presence System																																																										
1	2011	Yukon XL	Body	Radio																																																										
1	2011	Yukon XL	Body	Rear Heated Seat Module																																																										
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																										
1	2011	Yukon XL	Body	Right Side Object Detection Module																																																										
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon XL	Body	Theft Deterrent Module																																																										
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																	V										
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																	V										
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module									V	V	V																																															
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																									V	V	V	V				V	V									
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																									V	V	V															
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																							V					V														
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																									V	V	V	V				V	V									
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																									V	V	V															
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES					V																																																					
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES					V																																																					
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																						
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
1	2012	Sierra	Chassis	Electronic Suspension Control																																																										
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																										
1	2012	Sierra	Body	Amplifier (Bose)																																																										
1	2012	Sierra	Body	Body Control Module																																																										
1	2012	Sierra	Body	Body Control Module (aux.)																																																										
1	2012	Sierra	Body	Digital Radio Receiver																																																										
1	2012	Sierra	Body	Driver Door Switch																																																										
1	2012	Sierra	Body	HVAC Control Module Auto						V																																												V										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2012	Sierra	Body	HVAC Control Module Manual						V																																																					
1	2012	Sierra	Body	Instrument Panel Cluster																																																											
1	2012	Sierra	Body	Memory Seat Module							V																																																			
1	2012	Sierra	Body	Park Assist Module																																																										
1	2012	Sierra	Body	Passenger Door Switch																																																										
1	2012	Sierra	Body	Passenger Presence System																																																										
1	2012	Sierra	Body	Radio																																																										
1	2012	Sierra	Body	Navigation Radio																																																										
1	2012	Sierra	Body	Rear Heated Seat Module																																																										
1	2012	Sierra	Body	Rear HVAC/RSA																																																										
1	2012	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2012	Sierra	Body	Theft Deterrent Module																																																										
1	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																		V	V		V	V				
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																					V	V			
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																		V																						V	V
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
1	2012	Sierra Hybrid	Body	Body Control Module																																																										
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2012	Sierra Hybrid	Body	Driver Door Switch																																																										
1	2012	Sierra Hybrid	Body	Heated Seat Module																																																										
1	2012	Sierra Hybrid	Body	HVAC Control Module						V																																													V							
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2012	Sierra Hybrid	Body	Park Assist Module																																																										
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																																										
1	2012	Sierra Hybrid	Body	Passenger Presence System																																																										
1	2012	Sierra Hybrid	Body	Radio																																																										
1	2012	Sierra Hybrid	Body	Navigation Radio																																																										
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																														
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2012	Yukon	Chassis	Electronic Brake Control Module					V																																																					
1	2012	Yukon	Chassis	Electronic Suspension Control																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																											
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon	Body	Amplifier (Bose)																																																											
1	2012	Yukon	Body	Assist Step Controller																																																											
1	2012	Yukon	Body	Body Control Module																																																											
1	2012	Yukon	Body	Body Control Module (aux.)																																																											
1	2012	Yukon	Body	Digital Radio Receiver																																																											
1	2012	Yukon	Body	Driver Door Switch																																																											
1	2012	Yukon	Body	HVAC Control Module Auto						V																																								V												
1	2012	Yukon	Body	HVAC Control Module Manual						V																																																					
1	2012	Yukon	Body	Instrument Panel Cluster																																																											
1	2012	Yukon	Body	Left Side Object Detection Module																																																											
1	2012	Yukon	Body	Lift Gate Module																																																											
1	2012	Yukon	Body	Memory Seat Module							V																																																			
1	2012	Yukon	Body	Park Assist Module																																																											
1	2012	Yukon	Body	Passenger Door Switch																																																											
1	2012	Yukon	Body	Passenger Presence System																																																											
1	2012	Yukon	Body	Radio																																																											
1	2012	Yukon	Body	Navigation Radio																																																											
1	2012	Yukon	Body	Rear Heated Seat Module																																																											
1	2012	Yukon	Body	Rear HVAC/RSA																																																											
1	2012	Yukon	Body	Right Side Object Detection Module																																																											
1	2012	Yukon	Body	Supplemental Inflatable Restraint																																																											
1	2012	Yukon	Body	Theft Deterrent Module																																																											
1	2012	Yukon Hybrid	Powertrain	Engine Control Module																																															V	V		V	V						
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																				V	V				
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																			V																					V	V
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																											
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																											
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																											
1	2012	Yukon Hybrid	Body	Body Control Module																																																											
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																											
1	2012	Yukon Hybrid	Body	Driver Door Switch																																																											
1	2012	Yukon Hybrid	Body	Heated Seat Module																																																											
1	2012	Yukon Hybrid	Body	HVAC Control Module						V																																												V								
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
1	2012	Yukon Hybrid	Body	Lift Gate Module																																																											
1	2012	Yukon Hybrid	Body	Park Assist Module																																																											
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																																											
1	2012	Yukon Hybrid	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2012	Yukon Hybrid	Body	Radio																																																										
1	2012	Yukon Hybrid	Body	Navigation Radio																																																										
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																										
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																															
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW					V																																																					
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW				V																																																						
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																										
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2012	Yukon XL	Body	Amplifier (Bose)																																																										
1	2012	Yukon XL	Body	Assist Step Controller																																																										
1	2012	Yukon XL	Body	Body Control Module																																																										
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2012	Yukon XL	Body	Digital Radio Receiver																																																										
1	2012	Yukon XL	Body	Driver Door Switch																																																										
1	2012	Yukon XL	Body	HVAC Control Module Auto						V																																											V									
1	2012	Yukon XL	Body	HVAC Control Module Manual						V																																																				
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																										
1	2012	Yukon XL	Body	Left Side Object Detection Module																																																										
1	2012	Yukon XL	Body	Lift Gate Module																																																										
1	2012	Yukon XL	Body	Memory Seat Module							V																																																			
1	2012	Yukon XL	Body	Park Assist Module																																																										
1	2012	Yukon XL	Body	Passenger Door Switch																																																										
1	2012	Yukon XL	Body	Passenger Presence System																																																										
1	2012	Yukon XL	Body	Radio																																																										
1	2012	Yukon XL	Body	Navigation Radio																																																										
1	2012	Yukon XL	Body	Rear Heated Seat Module																																																										
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																										
1	2012	Yukon XL	Body	Right Side Object Detection Module																																																										
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
1	2012	Yukon XL	Body	Theft Deterrent Module																																																										
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																	V									
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																	V									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module									V	V	V																																															
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V	V	V	V				V	V									
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								V	V	V															
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																							V					V														
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES					V																																																					
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES					V																																																					
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES				V																																																						
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																										
1	2013	Sierra	Chassis	Electronic Suspension Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Body	Amplifier (Bose)																																																										
1	2013	Sierra	Body	Body Control Module																																																										
1	2013	Sierra	Body	Body Control Module (aux.)																																																										
1	2013	Sierra	Body	Digital Radio Receiver																																																										
1	2013	Sierra	Body	Driver Door Switch																																																										
1	2013	Sierra	Body	HVAC Control Module Auto						V																																								V											
1	2013	Sierra	Body	HVAC Control Module Manual						V																																																				
1	2013	Sierra	Body	Instrument Panel Cluster																																																										
1	2013	Sierra	Body	Memory Seat Module							V																																																			
1	2013	Sierra	Body	Park Assist Module																																																										
1	2013	Sierra	Body	Passenger Door Switch																																																										
1	2013	Sierra	Body	Passenger Presence System																																																										
1	2013	Sierra	Body	Radio																																																										
1	2013	Sierra	Body	Navigation Radio																																																										
1	2013	Sierra	Body	Rear Heated Seat Module																																																										
1	2013	Sierra	Body	Rear HVAC/RSA																																																										
1	2013	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2013	Sierra	Body	Theft Deterrent Module																																																										
1	2013	Sierra Hybrid	Powertrain	Engine Control Module																																														V	V		V	V						
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																					V	V				
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																			V																					V	V
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																											
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																											
1	2013	Sierra Hybrid	Body	Body Control Module																																																											
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																											
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																											
1	2013	Sierra Hybrid	Body	Driver Door Switch																																																											
1	2013	Sierra Hybrid	Body	Heated Seat Module																																																											
1	2013	Sierra Hybrid	Body	HVAC Control Module						V																																															V						
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																											
1	2013	Sierra Hybrid	Body	Park Assist Module																																																											
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																																											
1	2013	Sierra Hybrid	Body	Passenger Presence System																																																											
1	2013	Sierra Hybrid	Body	Radio																																																											
1	2013	Sierra Hybrid	Body	Navigation Radio																																																											
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																											
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																											
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																											
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																											
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																											
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																																
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																																
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																											
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
1	2013	Yukon	Chassis	Electronic Brake Control Module					V																																																						
1	2013	Yukon	Chassis	Electronic Suspension Control																																																											
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Yukon	Body	Amplifier (Bose)																																																											
1	2013	Yukon	Body	Assist Step Controller																																																											
1	2013	Yukon	Body	Body Control Module																																																											
1	2013	Yukon	Body	Body Control Module (aux.)																																																											
1	2013	Yukon	Body	Digital Radio Receiver																																																											
1	2013	Yukon	Body	Driver Door Switch																																																											
1	2013	Yukon	Body	HVAC Control Module Auto						V																																																					
1	2013	Yukon	Body	HVAC Control Module Manual						V																																																					
1	2013	Yukon	Body	Instrument Panel Cluster																																																											
1	2013	Yukon	Body	Left Side Object Detection Module																																																											
1	2013	Yukon	Body	Lift Gate Module																																																											
1	2013	Yukon	Body	Memory Seat Module							V																																																				
1	2013	Yukon	Body	Park Assist Module																																																											
1	2013	Yukon	Body	Passenger Door Switch																																																											
1	2013	Yukon	Body	Passenger Presence System																																																											
1	2013	Yukon	Body	Radio																																																											
1	2013	Yukon	Body	Navigation Radio																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2013	Yukon	Body	Rear Heated Seat Module																																																											
1	2013	Yukon	Body	Rear HVAC/RSA																																																											
1	2013	Yukon	Body	Right Side Object Detection Module																																																										
1	2013	Yukon	Body	Supplemental Inflatable Restraint																																																										
1	2013	Yukon	Body	Theft Deterrent Module																																																										
1	2013	Yukon Hybrid	Powertrain	Engine Control Module																																															V	V		V	V				
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																			V	V			
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																		V																					V	V
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2013	Yukon Hybrid	Body	Body Control Module																																																										
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2013	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2013	Yukon Hybrid	Body	Heated Seat Module																																																										
1	2013	Yukon Hybrid	Body	HVAC Control Module						V																																												V								
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
1	2013	Yukon Hybrid	Body	Lift Gate Module																																																										
1	2013	Yukon Hybrid	Body	Park Assist Module																																																										
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2013	Yukon Hybrid	Body	Passenger Presence System																																																										
1	2013	Yukon Hybrid	Body	Radio																																																										
1	2013	Yukon Hybrid	Body	Navigation Radio																																																										
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																										
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																														
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																														
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																														
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW					V																																																						
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW				V																																																							
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																											
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																											
1	2013	Yukon XL	Body	Amplifier (Bose)																																																											
1	2013	Yukon XL	Body	Assist Step Controller																																																											
1	2013	Yukon XL	Body	Body Control Module																																																											
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																											
1	2013	Yukon XL	Body	Digital Radio Receiver																																																											
1	2013	Yukon XL	Body	Driver Door Switch																																																											
1	2013	Yukon XL	Body	HVAC Control Module Auto						V																																											V										
1	2013	Yukon XL	Body	HVAC Control Module Manual						V																																																					
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																											
1	2013	Yukon XL	Body	Left Side Object Detection Module																																																											
1	2013	Yukon XL	Body	Lift Gate Module																																																											
1	2013	Yukon XL	Body	Memory Seat Module							V																																																				
1	2013	Yukon XL	Body	Park Assist Module																																																											
1	2013	Yukon XL	Body	Passenger Door Switch																																																											
1	2013	Yukon XL	Body	Passenger Presence System																																																											
1	2013	Yukon XL	Body	Radio																																																											
1	2013	Yukon XL	Body	Navigation Radio																																																											
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																											
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																											
1	2013	Yukon XL	Body	Right Side Object Detection Module																																																											
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
1	2013	Yukon XL	Body	Theft Deterrent Module																																																											
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																											
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
1	2014	Sierra	Chassis	Electronic Brake Control Module																																																											
1	2014	Sierra	Chassis	Parking Brake Control Module																																																											
1	2014	Sierra	Chassis	Power Steering Control Module																														V	V																												
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2014	Sierra	Body	Body Control Module																																																											
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	Sierra	Body	Passenger Presence Module																																																											
1	2014	Sierra	Body	Instrument Cluster																																																											
1	2014	Sierra	Body	Radio Control																																																											
1	2014	Sierra	Body	HVAC Control																																																											
1	2014	Sierra	Body	Radio																																																											
1	2014	Sierra	Body	Amplifier																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2014	Sierra	Body	Media Disc Player																																																										
1	2014	Sierra	Body	Human Machine Interface Control Module																																																										
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2014	Sierra	Body	Parking Assist Control Module																																																										
1	2014	Sierra	Body	Frontview Camera Module																																																										
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																								V																		
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																										
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Suspension Control Module																																																										
1	2014	Sierra HD	Body	Body Control Module																																																										
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Sierra HD	Body	Instrument Cluster																																																										
1	2014	Sierra HD	Body	Base Radio																																																										
1	2014	Sierra HD	Body	Navigation Radio																																																										
1	2014	Sierra HD	Body	Uplevel Radio																																																										
1	2014	Sierra HD	Body	Amplifier																																																										
1	2014	Sierra HD	Body	Rear Audio Control Module																																																										
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																										
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																										
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Sierra HD	Body	Seat Memory Control Module																																																										
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																										
1	2014	Sierra HD	Body	Parking Assist Control Module																									V																																	
1	2014	Sierra HD	Body	Theft Deterrent Module																																																										
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																										
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																							V																																			
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																														V																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
1	2014	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2014	Yukon	Chassis	Parking Brake Control Module																																																										
1	2014	Yukon	Chassis	Suspension Control Module																																																										
1	2014	Yukon	Body	Body Control Module																																																										
1	2014	Yukon	Body	Auxiliary Body Control Module																																																										
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Yukon	Body	Passenger Presence Module																																																										
1	2014	Yukon	Body	Instrument Cluster																																																										
1	2014	Yukon	Body	Base Radio																																																										
1	2014	Yukon	Body	Navigation Radio																																																										
1	2014	Yukon	Body	Uplevel Radio																																																										
1	2014	Yukon	Body	Amplifier																																																										
1	2014	Yukon	Body	Rear Audio Control Module																																																										
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																																										
1	2014	Yukon	Body	Personal Audio Link Control Module																																																										
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Yukon	Body	Liftgate Control Module																																																										
1	2014	Yukon	Body	Seat Memory Control Module																																																										
1	2014	Yukon	Body	Rear Seat Heating Control Module																																																										
1	2014	Yukon	Body	Assist Step Control Module																								V																																		
1	2014	Yukon	Body	Right Side Object Detection Control Module																																																										
1	2014	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																																										
1	2014	Yukon	Body	Parking Assist Control Module																									V																																	
1	2014	Yukon	Body	Theft Deterrent Module																																																										
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																										
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																										
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																										
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																							V																																		
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																												
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																												
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2014	Yukon XL	Chassis	Suspension Control Module																																																										
1	2014	Yukon XL	Body	Body Control Module																																																										
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																																										
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Yukon XL	Body	Passenger Presence Module																																																										
1	2014	Yukon XL	Body	Instrument Cluster																																																										
1	2014	Yukon XL	Body	Base Radio																																																										
1	2014	Yukon XL	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2014	Yukon XL	Body	Uplevel Radio																																																											
1	2014	Yukon XL	Body	Amplifier																																																											
1	2014	Yukon XL	Body	Rear Audio Control Module																																																											
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																											
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																																											
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																											
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																											
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																											
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																											
1	2014	Yukon XL	Body	Liftgate Control Module																																																											
1	2014	Yukon XL	Body	Seat Memory Control Module																																																											
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																											
1	2014	Yukon XL	Body	Assist Step Control Module																								V																																				
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																											
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																											
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																											
1	2014	Yukon XL	Body	Parking Assist Control Module																									V																																		
1	2014	Yukon XL	Body	Theft Deterrent Module																																																											
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																									V																		
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																											
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																											
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																	
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																											
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																													V																														
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																													V																														
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
1	2015	Sierra	Chassis	Electronic Brake Control Module																																																											
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																											
1	2015	Sierra	Chassis	Power Steering Control Module																														V	V																												
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2015	Sierra	Chassis	Suspension Control Module																																																											
1	2015	Sierra	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Sierra	Body	Passenger Presence Module																																																										
1	2015	Sierra	Body	Instrument Cluster																																																										
1	2015	Sierra	Body	Radio Controls																																																										
1	2015	Sierra	Body	HVAC Controls																																																										
1	2015	Sierra	Body	Radio																																																										
1	2015	Sierra	Body	Amplifier																																																										
1	2015	Sierra	Body	Media Disc Player																																																										
1	2015	Sierra	Body	Human Machine Interface Control Module																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2015	Sierra	Body	Parking Assist Control Module																																																										
1	2015	Sierra	Body	Frontview Camera Module																																																										
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																															
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																							V					V																														
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																													V																													
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																										
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																										
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																										
1	2015	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Yukon	Chassis	Parking Brake Control Module																																																										
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	Yukon	Chassis	Power Steering Control Module																														V	V																											
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Yukon	Chassis	Suspension Control Module																																																										
1	2015	Yukon	Body	Body Control Module																																																										
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Yukon	Body	Passenger Presence Module																																																										
1	2015	Yukon	Body	Instrument Cluster																																																										
1	2015	Yukon	Body	Radio Controls																																																										
1	2015	Yukon	Body	HVAC Controls																																																										
1	2015	Yukon	Body	Radio																																																										
1	2015	Yukon	Body	Amplifier																																																										
1	2015	Yukon	Body	Media Disc Player																																																										
1	2015	Yukon	Body	Human Machine Interface Control Module																																																										
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2015	Yukon	Body	HVAC Control Module																																																										
1	2015	Yukon	Body	Liftgate Control Module																																																										
1	2015	Yukon	Body	Keyless Entry Control Module																																																										
1	2015	Yukon	Body	Assist Step Control Module																																																										
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon	Body	Parking Assist Control Module																																																										
1	2015	Yukon	Body	Frontview Camera Module																																																										
1	2015	Yukon	Body	Steering Column Lock Control Module																																																										
1	2015	Yukon	Body	Battery Energy Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																															
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																							V					V																														
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																													V																													
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	Yukon XL	Chassis	Power Steering Control Module																														V	V																											
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Yukon XL	Chassis	Suspension Control Module																																																										
1	2015	Yukon XL	Body	Body Control Module																																																										
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Yukon XL	Body	Passenger Presence Module																																																										
1	2015	Yukon XL	Body	Instrument Cluster																																																										
1	2015	Yukon XL	Body	Radio Controls																																																										
1	2015	Yukon XL	Body	HVAC Controls																																																										
1	2015	Yukon XL	Body	Radio																																																										
1	2015	Yukon XL	Body	Amplifier																																																										
1	2015	Yukon XL	Body	Media Disc Player																																																										
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Yukon XL	Body	HVAC Control Module																																																										
1	2015	Yukon XL	Body	Liftgate Control Module																																																										
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
1	2015	Yukon XL	Body	Assist Step Control Module																																																										
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon XL	Body	Parking Assist Control Module																																																										
1	2015	Yukon XL	Body	Frontview Camera Module																																																										
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																											
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																											
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																											
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																											
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																											
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																								V																		
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																													V																														
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
1	2016	Sierra	Chassis	Electronic Brake Control Module																																																											
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																											
1	2016	Sierra	Chassis	Parking Brake Control Module																																																											
1	2016	Sierra	Chassis	Power Steering Control Module																																																											
1	2016	Sierra	Chassis	Power Steering Control Module																														V	V																												
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	Sierra	Chassis	Suspension Control Module																																																											
1	2016	Sierra	Body	Body Control Module																																																											
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2016	Sierra	Body	Passenger Presence Module																																																											
1	2016	Sierra	Body	Instrument Cluster																																																											
1	2016	Sierra	Body	Radio Controls																																																											
1	2016	Sierra	Body	HVAC Controls																																																											
1	2016	Sierra	Body	Radio (IO3)																																																											
1	2016	Sierra	Body	Radio (IOB)																																																											
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																											
1	2016	Sierra	Body	Amplifier																																																											
1	2016	Sierra	Body	Media Disc Player																																																											
1	2016	Sierra	Body	Human Machine Interface Control Module																																																											
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																											
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																											
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																											
1	2016	Sierra	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2016	Sierra	Body	Frontview Camera Module																																																											
1	2016	Sierra	Body	Frontview Camera Module																																																											
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																															
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																															
1	2016	Yukon	Chassis	Electronic Brake Control Module																																																											
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																											
1	2016	Yukon	Chassis	Parking Brake Control Module																																																											
1	2016	Yukon	Chassis	Power Steering Control Module																														V	V																													
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	Yukon	Chassis	Suspension Control Module																																																											
1	2016	Yukon	Body	Body Control Module																																																											
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2016	Yukon	Body	Passenger Presence Module																																																											
1	2016	Yukon	Body	Instrument Cluster																																																											
1	2016	Yukon	Body	Radio Controls																																																											
1	2016	Yukon	Body	HVAC Controls																																																											
1	2016	Yukon	Body	Radio																																																											
1	2016	Yukon	Body	Amplifier																																																											
1	2016	Yukon	Body	Media Disc Player																																																											
1	2016	Yukon	Body	Human Machine Interface Control Module																																																											
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																											
1	2016	Yukon	Body	HVAC Control Module																																																											
1	2016	Yukon	Body	Liftgate Control Module																																																											
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																											
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																											
1	2016	Yukon	Body	Keyless Entry Control Module																																																											
1	2016	Yukon	Body	Assist Step Control Module																																																											
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																											
1	2016	Yukon	Body	Parking Assist Control Module																																																											
1	2016	Yukon	Body	Frontview Camera Module																																																											
1	2016	Yukon	Body	Steering Column Lock Control Module																																																											
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																															
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																															
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																											
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																											
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																											
1	2016	Yukon XL	Chassis	Power Steering Control Module																														V	V																												
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	Yukon XL	Chassis	Suspension Control Module																																																											
1	2016	Yukon XL	Body	Body Control Module																																																											
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
1	2016	Yukon XL	Body	Passenger Presence Module																																																										
1	2016	Yukon XL	Body	Instrument Cluster																																																										
1	2016	Yukon XL	Body	Radio Controls																																																										
1	2016	Yukon XL	Body	HVAC Controls																																																										
1	2016	Yukon XL	Body	Radio																																																										
1	2016	Yukon XL	Body	Amplifier																																																										
1	2016	Yukon XL	Body	Media Disc Player																																																										
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																										
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																										
1	2016	Yukon XL	Body	HVAC Control Module																																																										
1	2016	Yukon XL	Body	Liftgate Control Module																																																										
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																										
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																										
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																										
1	2016	Yukon XL	Body	Assist Step Control Module																																																										
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2016	Yukon XL	Body	Parking Assist Control Module																																																										
1	2016	Yukon XL	Body	Frontview Camera Module																																																										
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																										
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module											V	V																																														
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																															
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module											V	V																																														
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																							V	V	V	V			V	V										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																							V	V	V															
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																						V					V															
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																							V	V	V	V			V	V										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																							V	V	V															
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																						V					V															
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES					V																																																						
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES					V																																																						
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																							
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
2	2011	Sierra	Chassis	Electronic Suspension Control																																																											
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																											
2	2011	Sierra	Body	Amplifier (Bose)																																																											
2	2011	Sierra	Body	Body Control Module																																																											
2	2011	Sierra	Body	Body Control Module (aux.)																																																											
2	2011	Sierra	Body	Digital Radio Receiver																																																											
2	2011	Sierra	Body	Driver Door Switch																																																											
2	2011	Sierra	Body	HVAC Control Module Auto						V																																										V										
2	2011	Sierra	Body	HVAC Control Module Manual						V																																																					
2	2011	Sierra	Body	Instrument Panel Cluster																																																											
2	2011	Sierra	Body	Memory Seat Module							V																																																				
2	2011	Sierra	Body	Park Assist Module																																																											
2	2011	Sierra	Body	Passenger Door Switch																																																											
2	2011	Sierra	Body	Passenger Presence System																																																											
2	2011	Sierra	Body	Radio																																																											
2	2011	Sierra	Body	Rear Heated Seat Module																																																											
2	2011	Sierra	Body	Rear HVAC/RSA																																																											
2	2011	Sierra	Body	Supplemental Inflatable Restraint																																																											
2	2011	Sierra	Body	Theft Deterrent Module																																																											
2	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																V	V		V	V					
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																											
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																				V	V				
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																			V																						V	V
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																											
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																											
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																											
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																											
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																																											
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																											
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																											
2	2011	Sierra Hybrid	Body	Body Control Module																																																											
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																											
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																											
2	2011	Sierra Hybrid	Body	Driver Door Switch																																																											
2	2011	Sierra Hybrid	Body	Heated Seat Module																																																											
2	2011	Sierra Hybrid	Body	HVAC Control Module						V																																												V									
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																											
2	2011	Sierra Hybrid	Body	Park Assist Module																																																											
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																																											
2	2011	Sierra Hybrid	Body	Passenger Presence System																																																											
2	2011	Sierra Hybrid	Body	Radio																																																											
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																											
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																															
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2011	Yukon	Chassis	Electronic Brake Control Module				V																																																						
2	2011	Yukon	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																										
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon	Body	Amplifier (Bose)																																																										
2	2011	Yukon	Body	Assist Step Controller																																																										
2	2011	Yukon	Body	Body Control Module																																																										
2	2011	Yukon	Body	Body Control Module (aux.)																																																										
2	2011	Yukon	Body	Digital Radio Receiver																																																										
2	2011	Yukon	Body	Driver Door Switch																																																										
2	2011	Yukon	Body	HVAC Control Module Auto						V																																									V											
2	2011	Yukon	Body	HVAC Control Module Manual						V																																																				
2	2011	Yukon	Body	Instrument Panel Cluster																																																										
2	2011	Yukon	Body	Left Side Object Detection Module																																																										
2	2011	Yukon	Body	Lift Gate Module																																																										
2	2011	Yukon	Body	Memory Seat Module							V																																																			
2	2011	Yukon	Body	Park Assist Module																																																										
2	2011	Yukon	Body	Passenger Door Switch																																																										
2	2011	Yukon	Body	Passenger Presence System																																																										
2	2011	Yukon	Body	Radio																																																										
2	2011	Yukon	Body	Rear Heated Seat Module																																																										
2	2011	Yukon	Body	Rear HVAC/RSA																																																										
2	2011	Yukon	Body	Right Side Object Detection Module																																																										
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2011	Yukon	Body	Theft Deterrent Module																																																										
2	2011	Yukon Hybrid	Powertrain	Engine Control Module																																															V	V		V	V							
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																				V	V				
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																			V																					V	V	
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2011	Yukon Hybrid	Body	Body Control Module																																																										
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2011	Yukon Hybrid	Body	Driver Door Switch																																																										
2	2011	Yukon Hybrid	Body	Heated Seat Module																																																										
2	2011	Yukon Hybrid	Body	HVAC Control Module						V																																														V						
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
2	2011	Yukon Hybrid	Body	Lift Gate Module																																																										
2	2011	Yukon Hybrid	Body	Park Assist Module																																																										
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																																										
2	2011	Yukon Hybrid	Body	Passenger Presence System																																																										
2	2011	Yukon Hybrid	Body	Radio																																																										
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module									V	V	V																																															
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module											V	V																																														
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																															
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW					V																																																					
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW				V																																																						
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																										
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																										
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Yukon XL	Body	Amplifier (Bose)																																																										
2	2011	Yukon XL	Body	Assist Step Controller																																																										
2	2011	Yukon XL	Body	Body Control Module																																																										
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																										
2	2011	Yukon XL	Body	Digital Radio Receiver																																																										
2	2011	Yukon XL	Body	Driver Door Switch																																																										
2	2011	Yukon XL	Body	HVAC Control Module Auto						V																																									V											
2	2011	Yukon XL	Body	HVAC Control Module Manual						V																																																				
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																										
2	2011	Yukon XL	Body	Left Side Object Detection Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2011	Yukon XL	Body	Lift Gate Module																																																											
2	2011	Yukon XL	Body	Memory Seat Module							V																																																			
2	2011	Yukon XL	Body	Park Assist Module																																																										
2	2011	Yukon XL	Body	Passenger Door Switch																																																										
2	2011	Yukon XL	Body	Passenger Presence System																																																										
2	2011	Yukon XL	Body	Radio																																																										
2	2011	Yukon XL	Body	Rear Heated Seat Module																																																										
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																										
2	2011	Yukon XL	Body	Right Side Object Detection Module																																																										
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
2	2011	Yukon XL	Body	Theft Deterrent Module																																																										
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																													V													
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																													V													
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module									V	V	V																																															
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								V	V	V	V				V	V										
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								V	V	V															
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																										
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																							V						V												
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																										
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V	V	V	V				V	V										
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								V	V	V															
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								V						V												
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES					V																																																					
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES					V																																																					
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES				V																																																						
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
2	2012	Sierra	Chassis	Electronic Suspension Control																																																										
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																										
2	2012	Sierra	Body	Amplifier (Bose)																																																										
2	2012	Sierra	Body	Body Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2012	Sierra	Body	Body Control Module (aux.)																																																												
2	2012	Sierra	Body	Digital Radio Receiver																																																												
2	2012	Sierra	Body	Driver Door Switch																																																												
2	2012	Sierra	Body	HVAC Control Module Auto						V																																									V											
2	2012	Sierra	Body	HVAC Control Module Manual						V																																																					
2	2012	Sierra	Body	Instrument Panel Cluster																																																											
2	2012	Sierra	Body	Memory Seat Module							V																																																			
2	2012	Sierra	Body	Park Assist Module																																																											
2	2012	Sierra	Body	Passenger Door Switch																																																											
2	2012	Sierra	Body	Passenger Presence System																																																											
2	2012	Sierra	Body	Radio																																																											
2	2012	Sierra	Body	Navigation Radio																																																											
2	2012	Sierra	Body	Rear Heated Seat Module																																																											
2	2012	Sierra	Body	Rear HVAC/RSA																																																											
2	2012	Sierra	Body	Supplemental Inflatable Restraint																																																											
2	2012	Sierra	Body	Theft Deterrent Module																																																											
2	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																V	V		V	V					
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																											
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																				V	V				
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																											
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																		V																						V	V
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																																										
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Sierra Hybrid	Body	Body Control Module																																																										
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2012	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	HVAC Control Module						V																																												V									
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2012	Sierra Hybrid	Body	Park Assist Module																																																										
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2012	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2012	Sierra Hybrid	Body	Radio																																																										
2	2012	Sierra Hybrid	Body	Navigation Radio																																																										
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																															
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2012	Yukon	Chassis	Electronic Brake Control Module					V																																																					
2	2012	Yukon	Chassis	Electronic Suspension Control																																																										
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																										
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Yukon	Body	Amplifier (Bose)																																																										
2	2012	Yukon	Body	Assist Step Controller																																																										
2	2012	Yukon	Body	Body Control Module																																																										
2	2012	Yukon	Body	Body Control Module (aux.)																																																										
2	2012	Yukon	Body	Digital Radio Receiver																																																										
2	2012	Yukon	Body	Driver Door Switch																																																										
2	2012	Yukon	Body	HVAC Control Module Auto						V																																										V										
2	2012	Yukon	Body	HVAC Control Module Manual						V																																																				
2	2012	Yukon	Body	Instrument Panel Cluster																																																										
2	2012	Yukon	Body	Left Side Object Detection Module																																																										
2	2012	Yukon	Body	Lift Gate Module																																																										
2	2012	Yukon	Body	Memory Seat Module							V																																																			
2	2012	Yukon	Body	Park Assist Module																																																										
2	2012	Yukon	Body	Passenger Door Switch																																																										
2	2012	Yukon	Body	Passenger Presence System																																																										
2	2012	Yukon	Body	Radio																																																										
2	2012	Yukon	Body	Navigation Radio																																																										
2	2012	Yukon	Body	Rear Heated Seat Module																																																										
2	2012	Yukon	Body	Rear HVAC/RSA																																																										
2	2012	Yukon	Body	Right Side Object Detection Module																																																										
2	2012	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2012	Yukon	Body	Theft Deterrent Module																																																										
2	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																V	V		V	V					
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																				V	V			
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																		V																						V	V
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2012	Yukon Hybrid	Body	Body Control Module																																																										
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Yukon Hybrid	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2012	Yukon Hybrid	Body	Heated Seat Module																																																												
2	2012	Yukon Hybrid	Body	HVAC Control Module						V																																														V						
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
2	2012	Yukon Hybrid	Body	Lift Gate Module																																																										
2	2012	Yukon Hybrid	Body	Park Assist Module																																																										
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																																										
2	2012	Yukon Hybrid	Body	Passenger Presence System																																																										
2	2012	Yukon Hybrid	Body	Radio																																																										
2	2012	Yukon Hybrid	Body	Navigation Radio																																																										
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																										
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																										
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																										
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																															
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW					V																																																					
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW				V																																																						
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																										
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																										
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Yukon XL	Body	Amplifier (Bose)																																																										
2	2012	Yukon XL	Body	Assist Step Controller																																																										
2	2012	Yukon XL	Body	Body Control Module																																																										
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																										
2	2012	Yukon XL	Body	Digital Radio Receiver																																																										
2	2012	Yukon XL	Body	Driver Door Switch																																																										
2	2012	Yukon XL	Body	HVAC Control Module Auto						V																																											V									
2	2012	Yukon XL	Body	HVAC Control Module Manual						V																																																				
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																										
2	2012	Yukon XL	Body	Left Side Object Detection Module																																																										
2	2012	Yukon XL	Body	Lift Gate Module																																																										
2	2012	Yukon XL	Body	Memory Seat Module							V																																																		
2	2012	Yukon XL	Body	Park Assist Module																																																										
2	2012	Yukon XL	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2012	Yukon XL	Body	Passenger Presence System																																																										
2	2012	Yukon XL	Body	Radio																																																										
2	2012	Yukon XL	Body	Navigation Radio																																																										
2	2012	Yukon XL	Body	Rear Heated Seat Module																																																										
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																										
2	2012	Yukon XL	Body	Right Side Object Detection Module																																																										
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
2	2012	Yukon XL	Body	Theft Deterrent Module																																																										
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																										
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module									V	V	V																																															
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																										
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								V	V	V	V			V	V									
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								V	V	V														
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																						V						V														
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																										
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES					V																																																					
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES					V																																																					
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES				V																																																						
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																										
2	2013	Sierra	Chassis	Electronic Suspension Control																																																										
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Sierra	Body	Amplifier (Bose)																																																										
2	2013	Sierra	Body	Body Control Module																																																										
2	2013	Sierra	Body	Body Control Module (aux.)																																																										
2	2013	Sierra	Body	Digital Radio Receiver																																																										
2	2013	Sierra	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2013	Sierra	Body	HVAC Control Module Auto						V																																									V										
2	2013	Sierra	Body	HVAC Control Module Manual						V																																																			
2	2013	Sierra	Body	Instrument Panel Cluster																																																										
2	2013	Sierra	Body	Memory Seat Module							V																																																		
2	2013	Sierra	Body	Park Assist Module																																																									
2	2013	Sierra	Body	Passenger Door Switch																																																									
2	2013	Sierra	Body	Passenger Presence System																																																									
2	2013	Sierra	Body	Radio																																																									
2	2013	Sierra	Body	Navigation Radio																																																									
2	2013	Sierra	Body	Rear Heated Seat Module																																																									
2	2013	Sierra	Body	Rear HVAC/RSA																																																									
2	2013	Sierra	Body	Supplemental Inflatable Restraint																																																									
2	2013	Sierra	Body	Theft Deterrent Module																																																									
2	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																V	V		V	V				
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																									
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																				V	V			
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																									
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																		V																					V	V
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																									
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																									
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																									
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																									
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																									
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																									
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																									
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																																									
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																									
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																									
2	2013	Sierra Hybrid	Body	Body Control Module																																																									
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																									
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																									
2	2013	Sierra Hybrid	Body	Driver Door Switch																																																									
2	2013	Sierra Hybrid	Body	Heated Seat Module																																																									
2	2013	Sierra Hybrid	Body	HVAC Control Module						V																																														V								
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																									
2	2013	Sierra Hybrid	Body	Park Assist Module																																																									
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																																									
2	2013	Sierra Hybrid	Body	Passenger Presence System																																																									
2	2013	Sierra Hybrid	Body	Radio																																																									
2	2013	Sierra Hybrid	Body	Navigation Radio																																																									
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																									
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																									
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																									
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																									
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																									
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																														
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																									
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																									
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																									
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																															
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2013	Yukon	Chassis	Electronic Brake Control Module					V																																																					
2	2013	Yukon	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon	Body	Amplifier (Bose)																																																										
2	2013	Yukon	Body	Assist Step Controller																																																										
2	2013	Yukon	Body	Body Control Module																																																										
2	2013	Yukon	Body	Body Control Module (aux.)																																																										
2	2013	Yukon	Body	Digital Radio Receiver																																																										
2	2013	Yukon	Body	Driver Door Switch																																																										
2	2013	Yukon	Body	HVAC Control Module Auto						V																																										V										
2	2013	Yukon	Body	HVAC Control Module Manual						V																																																				
2	2013	Yukon	Body	Instrument Panel Cluster																																																										
2	2013	Yukon	Body	Left Side Object Detection Module																																																										
2	2013	Yukon	Body	Lift Gate Module																																																										
2	2013	Yukon	Body	Memory Seat Module							V																																																			
2	2013	Yukon	Body	Park Assist Module																																																										
2	2013	Yukon	Body	Passenger Door Switch																																																										
2	2013	Yukon	Body	Passenger Presence System																																																										
2	2013	Yukon	Body	Radio																																																										
2	2013	Yukon	Body	Navigation Radio																																																										
2	2013	Yukon	Body	Rear Heated Seat Module																																																										
2	2013	Yukon	Body	Rear HVAC/RSA																																																										
2	2013	Yukon	Body	Right Side Object Detection Module																																																										
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2013	Yukon	Body	Theft Deterrent Module																																																										
2	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																V	V		V	V					
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																				V	V			
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																			V																					V	V
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																										
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																																										
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2013	Yukon Hybrid	Body	Body Control Module																																																										
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2013	Yukon Hybrid	Body	Driver Door Switch																																																										
2	2013	Yukon Hybrid	Body	Heated Seat Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2013	Yukon Hybrid	Body	HVAC Control Module						V																																														V						
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
2	2013	Yukon Hybrid	Body	Lift Gate Module																																																										
2	2013	Yukon Hybrid	Body	Park Assist Module																																																										
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																																										
2	2013	Yukon Hybrid	Body	Passenger Presence System																																																										
2	2013	Yukon Hybrid	Body	Radio																																																										
2	2013	Yukon Hybrid	Body	Navigation Radio																																																										
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module									V	V	V																																															
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module									V	V	V																																															
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module									V	V	V																																															
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW					V																																																					
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW				V																																																						
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon XL	Body	Amplifier (Bose)																																																										
2	2013	Yukon XL	Body	Assist Step Controller																																																										
2	2013	Yukon XL	Body	Body Control Module																																																										
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																										
2	2013	Yukon XL	Body	Digital Radio Receiver																																																										
2	2013	Yukon XL	Body	Driver Door Switch																																																										
2	2013	Yukon XL	Body	HVAC Control Module Auto						V																																																				
2	2013	Yukon XL	Body	HVAC Control Module Manual						V																																																				
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																										
2	2013	Yukon XL	Body	Left Side Object Detection Module																																																										
2	2013	Yukon XL	Body	Lift Gate Module																																																										
2	2013	Yukon XL	Body	Memory Seat Module							V																																																		
2	2013	Yukon XL	Body	Park Assist Module																																																										
2	2013	Yukon XL	Body	Passenger Door Switch																																																										
2	2013	Yukon XL	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2013	Yukon XL	Body	Radio																																																											
2	2013	Yukon XL	Body	Navigation Radio																																																											
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																											
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																											
2	2013	Yukon XL	Body	Right Side Object Detection Module																																																											
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																											
2	2013	Yukon XL	Body	Theft Deterrent Module																																																											
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																											
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																											
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																											
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
2	2014	Sierra	Chassis	Electronic Brake Control Module																																																											
2	2014	Sierra	Chassis	Parking Brake Control Module																																																											
2	2014	Sierra	Chassis	Power Steering Control Module																														V	V																												
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2014	Sierra	Body	Body Control Module																																																											
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2014	Sierra	Body	Passenger Presence Module																																																											
2	2014	Sierra	Body	Instrument Cluster																																																											
2	2014	Sierra	Body	Radio Control																																																											
2	2014	Sierra	Body	HVAC Control																																																											
2	2014	Sierra	Body	Radio																																																											
2	2014	Sierra	Body	Amplifier																																																											
2	2014	Sierra	Body	Media Disc Player																																																											
2	2014	Sierra	Body	Human Machine Interface Control Module																																																											
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																											
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
2	2014	Sierra	Body	Parking Assist Control Module																																																											
2	2014	Sierra	Body	Frontview Camera Module																																																											
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																								V																			
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																											
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																											
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																											
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2014	Sierra HD	Chassis	Suspension Control Module																																																													
2	2014	Sierra HD	Body	Body Control Module																																																													
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
2	2014	Sierra HD	Body	Instrument Cluster																																																													
2	2014	Sierra HD	Body	Base Radio																																																													
2	2014	Sierra HD	Body	Navigation Radio																																																													
2	2014	Sierra HD	Body	Uplevel Radio																																																													
2	2014	Sierra HD	Body	Amplifier																																																													
2	2014	Sierra HD	Body	Rear Audio Control Module																																																													
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																													
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																													
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																													
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																													
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																													
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																													
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																													
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																													
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																													
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																													
2	2014	Sierra HD	Body	Seat Memory Control Module																																																													
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																													
2	2014	Sierra HD	Body	Parking Assist Control Module																									V																																				
2	2014	Sierra HD	Body	Theft Deterrent Module																																																													
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																													
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																													
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																													
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																													
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																													
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																							V																																					
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																												
2	2014	Yukon	Chassis	Parking Brake Control Module																																																												
2	2014	Yukon	Chassis	Suspension Control Module																																																												
2	2014	Yukon	Body	Body Control Module																																																												
2	2014	Yukon	Body	Auxiliary Body Control Module																																																												
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2014	Yukon	Body	Passenger Presence Module																																																												
2	2014	Yukon	Body	Instrument Cluster																																																												
2	2014	Yukon	Body	Base Radio																																																												
2	2014	Yukon	Body	Navigation Radio																																																												
2	2014	Yukon	Body	Uplevel Radio																																																												
2	2014	Yukon	Body	Amplifier																																																												
2	2014	Yukon	Body	Rear Audio Control Module																																																												
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																												
2	2014	Yukon	Body	Personal Audio Link Control Module																																																												
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																												
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																											
2	2014	Yukon	Body	Liftgate Control Module																																																												
2	2014	Yukon	Body	Seat Memory Control Module																																																											
2	2014	Yukon	Body	Rear Seat Heating Control Module																																																											
2	2014	Yukon	Body	Assist Step Control Module																								V																																				
2	2014	Yukon	Body	Right Side Object Detection Control Module																																																											
2	2014	Yukon	Body	Left Side Object Detection Control Module																																																											
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																											
2	2014	Yukon	Body	Parking Assist Control Module																									V																																			
2	2014	Yukon	Body	Theft Deterrent Module																																																											
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																											
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																											
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																											
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																							V																																				
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																										
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																										
2	2014	Yukon XL	Chassis	Suspension Control Module																																																										
2	2014	Yukon XL	Body	Body Control Module																																																										
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																										
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Yukon XL	Body	Passenger Presence Module																																																										
2	2014	Yukon XL	Body	Instrument Cluster																																																										
2	2014	Yukon XL	Body	Base Radio																																																										
2	2014	Yukon XL	Body	Navigation Radio																																																										
2	2014	Yukon XL	Body	Uplevel Radio																																																										
2	2014	Yukon XL	Body	Amplifier																																																										
2	2014	Yukon XL	Body	Rear Audio Control Module																																																										
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																										
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																										
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																										
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																										
2	2014	Yukon XL	Body	Liftgate Control Module																																																										
2	2014	Yukon XL	Body	Seat Memory Control Module																																																										
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																										
2	2014	Yukon XL	Body	Assist Step Control Module																								V																																			
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																										
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																										
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																										
2	2014	Yukon XL	Body	Parking Assist Control Module																									V																																			
2	2014	Yukon XL	Body	Theft Deterrent Module																																																										
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																											
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																								V																		
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																											
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																											
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																											
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																																	
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																											
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																													V																														
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																													V																														
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																														
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																														
2	2015	Sierra	Chassis	Electronic Brake Control Module																																																											
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																											
2	2015	Sierra	Chassis	Power Steering Control Module																														V	V																												
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2015	Sierra	Chassis	Suspension Control Module																																																											
2	2015	Sierra	Body	Body Control Module																																																											
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2015	Sierra	Body	Passenger Presence Module																																																											
2	2015	Sierra	Body	Instrument Cluster																																																											
2	2015	Sierra	Body	Radio Controls																																																											
2	2015	Sierra	Body	HVAC Controls																																																											
2	2015	Sierra	Body	Radio																																																											
2	2015	Sierra	Body	Amplifier																																																											
2	2015	Sierra	Body	Media Disc Player																																																											
2	2015	Sierra	Body	Human Machine Interface Control Module																																																											
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																											
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
2	2015	Sierra	Body	Parking Assist Control Module																																																											
2	2015	Sierra	Body	Frontview Camera Module																																																											
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																															
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																							V					V																															
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																													V																													
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																									
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																									
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																									
2	2015	Yukon	Chassis	Electronic Brake Control Module																																																									
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																									
2	2015	Yukon	Chassis	Parking Brake Control Module																																																									
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																									
2	2015	Yukon	Chassis	Power Steering Control Module																														V	V																											
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																									
2	2015	Yukon	Chassis	Suspension Control Module																																																									
2	2015	Yukon	Body	Body Control Module																																																									
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
2	2015	Yukon	Body	Passenger Presence Module																																																									
2	2015	Yukon	Body	Instrument Cluster																																																									
2	2015	Yukon	Body	Radio Controls																																																									
2	2015	Yukon	Body	HVAC Controls																																																									
2	2015	Yukon	Body	Radio																																																									
2	2015	Yukon	Body	Amplifier																																																									
2	2015	Yukon	Body	Media Disc Player																																																									
2	2015	Yukon	Body	Human Machine Interface Control Module																																																									
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																									
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																									
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																									
2	2015	Yukon	Body	HVAC Control Module																																																									
2	2015	Yukon	Body	Liftgate Control Module																																																									
2	2015	Yukon	Body	Keyless Entry Control Module																																																									
2	2015	Yukon	Body	Assist Step Control Module																																																									
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																									
2	2015	Yukon	Body	Parking Assist Control Module																																																									
2	2015	Yukon	Body	Frontview Camera Module																																																									
2	2015	Yukon	Body	Steering Column Lock Control Module																																																									
2	2015	Yukon	Body	Battery Energy Control Module																																																									
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																									
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																									
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																									
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																									
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																									
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																										V	V																															
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																									
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																							V					V																															
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																													V																													
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
2	2015	Yukon XL	Chassis	Power Steering Control Module																														V	V																											
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Yukon XL	Chassis	Suspension Control Module																																																										
2	2015	Yukon XL	Body	Body Control Module																																																										
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Yukon XL	Body	Passenger Presence Module																																																										
2	2015	Yukon XL	Body	Instrument Cluster																																																										
2	2015	Yukon XL	Body	Radio Controls																																																										
2	2015	Yukon XL	Body	HVAC Controls																																																										
2	2015	Yukon XL	Body	Radio																																																										
2	2015	Yukon XL	Body	Amplifier																																																										
2	2015	Yukon XL	Body	Media Disc Player																																																										
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Yukon XL	Body	HVAC Control Module																																																										
2	2015	Yukon XL	Body	Liftgate Control Module																																																										
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
2	2015	Yukon XL	Body	Assist Step Control Module																																																										
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
2	2015	Yukon XL	Body	Parking Assist Control Module																																																										
2	2015	Yukon XL	Body	Frontview Camera Module																																																										
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																						V																				
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																														V																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
2	2016	Sierra	Chassis	Electronic Brake Control Module																																																										
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																										
2	2016	Sierra	Chassis	Parking Brake Control Module																																																										
2	2016	Sierra	Chassis	Power Steering Control Module																																																										
2	2016	Sierra	Chassis	Power Steering Control Module																														V	V																												
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2016	Sierra	Chassis	Suspension Control Module																																																										
2	2016	Sierra	Body	Body Control Module																																																										
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2016	Sierra	Body	Passenger Presence Module																																																										
2	2016	Sierra	Body	Instrument Cluster																																																										
2	2016	Sierra	Body	Radio Controls																																																										
2	2016	Sierra	Body	HVAC Controls																																																										
2	2016	Sierra	Body	Radio (IO3)																																																										
2	2016	Sierra	Body	Radio (IOB)																																																										
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																										
2	2016	Sierra	Body	Amplifier																																																										
2	2016	Sierra	Body	Media Disc Player																																																										
2	2016	Sierra	Body	Human Machine Interface Control Module																																																										
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																										
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																										
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																										
2	2016	Sierra	Body	Parking Assist Control Module																																																										
2	2016	Sierra	Body	Frontview Camera Module																																																										
2	2016	Sierra	Body	Frontview Camera Module																																																										
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																													V																													
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																													V																													
2	2016	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																										
2	2016	Yukon	Chassis	Parking Brake Control Module																																																										
2	2016	Yukon	Chassis	Power Steering Control Module																														V	V																												
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2016	Yukon	Chassis	Suspension Control Module																																																										
2	2016	Yukon	Body	Body Control Module																																																										
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2016	Yukon	Body	Passenger Presence Module																																																										
2	2016	Yukon	Body	Instrument Cluster																																																										
2	2016	Yukon	Body	Radio Controls																																																										
2	2016	Yukon	Body	HVAC Controls																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
2	2016	Yukon	Body	Radio																																																										
2	2016	Yukon	Body	Amplifier																																																										
2	2016	Yukon	Body	Media Disc Player																																																										
2	2016	Yukon	Body	Human Machine Interface Control Module																																																										
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																										
2	2016	Yukon	Body	HVAC Control Module																																																										
2	2016	Yukon	Body	Liftgate Control Module																																																										
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																										
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																										
2	2016	Yukon	Body	Keyless Entry Control Module																																																										
2	2016	Yukon	Body	Assist Step Control Module																																																										
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																										
2	2016	Yukon	Body	Parking Assist Control Module																																																										
2	2016	Yukon	Body	Frontview Camera Module																																																										
2	2016	Yukon	Body	Steering Column Lock Control Module																																																										
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																														V																												
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																														V																												
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																										
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																										
2	2016	Yukon XL	Chassis	Power Steering Control Module																															V	V																										
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2016	Yukon XL	Chassis	Suspension Control Module																																																										
2	2016	Yukon XL	Body	Body Control Module																																																										
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2016	Yukon XL	Body	Passenger Presence Module																																																										
2	2016	Yukon XL	Body	Instrument Cluster																																																										
2	2016	Yukon XL	Body	Radio Controls																																																										
2	2016	Yukon XL	Body	HVAC Controls																																																										
2	2016	Yukon XL	Body	Radio																																																										
2	2016	Yukon XL	Body	Amplifier																																																										
2	2016	Yukon XL	Body	Media Disc Player																																																										
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																										
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																										
2	2016	Yukon XL	Body	HVAC Control Module																																																										
2	2016	Yukon XL	Body	Liftgate Control Module																																																										
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																										
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																										
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																										
2	2016	Yukon XL	Body	Assist Step Control Module																																																										
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																										
2	2016	Yukon XL	Body	Parking Assist Control Module																																																										
2	2016	Yukon XL	Body	Frontview Camera Module																																																										
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																										
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																														V												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										V		
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										V		
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
5	2011	ALL	Chassis	Electronic Brake Control Module																																																												
5	2011	ALL	Body	Body Control Module																																																											
5	2011	ALL	Body	Digital Radio Receiver																																																											
5	2011	ALL	Body	Generator Battery Control Module																																																											
5	2011	ALL	Body	Instrument Panel Cluster																																																											
5	2011	ALL	Body	Passenger Presence System																																																											
5	2011	ALL	Body	Personal Audio Link Module																																																											
5	2011	ALL	Body	Base Radio																																																											
5	2011	ALL	Body	Uplevel Radio																																																											
5	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
5	2011	ALL	Body	Theft Deterrent Module																																																											
5	2011	ALL	Body	Vehicle Comm. Interface Module																																																											
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										V		
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											V		
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											V		
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
5	2012	ALL	Chassis	Electronic Brake Control Module																																																												
5	2012	ALL	Body	Body Control Module																																																											
5	2012	ALL	Body	Digital Radio Receiver																																																											
5	2012	ALL	Body	Generator Battery Control Module																																																											
5	2012	ALL	Body	Instrument Panel Cluster																																																											
5	2012	ALL	Body	Passenger Presence System																																																											
5	2012	ALL	Body	Personal Audio Link Module																																																											
5	2012	ALL	Body	Base Radio																																																											
5	2012	ALL	Body	Uplevel Radio																																																											
5	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
5	2012	ALL	Body	Theft Deterrent Module																																																											
5	2012	ALL	Body	Vehicle Comm. Interface Module																																																											
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
5	2015	Canyon	Powertrain	Chassis Control Module																																																											
5	2015	Canyon	Powertrain	Transfer Case Control Module																													V																														
5	2015	Canyon	Chassis	Electronic Brake Control Module																																																											
5	2015	Canyon	Chassis	Power Steering Control Module																																																											
5	2015	Canyon	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
5	2015	Canyon	Body	Passenger Presence Module																																																												
5	2015	Canyon	Body	Radio																																																											
5	2015	Canyon	Body	Amplifier																																																											
5	2015	Canyon	Body	Human Machine Interface Control Module																																																											
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																																											
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																											
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																											
5	2015	Canyon	Body	Parking Assist Control Module																																																											
5	2015	Canyon	Body	Frontview Camera Module																																																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																											
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
5	2016	Canyon	Powertrain	Transfer Case Control Module																													V																															
5	2016	Canyon	Chassis	Electronic Brake Control Module																																																											
5	2016	Canyon	Chassis	Power Steering Control Module																																																											
5	2016	Canyon	Body	Body Control Module																																																											
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
5	2016	Canyon	Body	Passenger Presence Module																																																											
5	2016	Canyon	Body	Trailer Interface Control Module																																																											
5	2016	Canyon	Body	Radio																																																											
5	2016	Canyon	Body	Amplifier																																																											
5	2016	Canyon	Body	Human Machine Interface Control Module																																																											
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																																											
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																											
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																											
5	2016	Canyon	Body	Frontview Camera Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
6	2011	ALL	Chassis	Electronic Brake Control Module																																																											
6	2011	ALL	Body	Body Control Module																																																											
6	2011	ALL	Body	Digital Radio Receiver																																																											
6	2011	ALL	Body	Generator Battery Control Module																																																											
6	2011	ALL	Body	Instrument Panel Cluster																																																											
6	2011	ALL	Body	Passenger Presence System																																																											
6	2011	ALL	Body	Personal Audio Link Module																																																											
6	2011	ALL	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
6	2011	ALL	Body	Uplevel Radio																																																										
6	2011	ALL	Body	Supplemental Inflatable Restraint																																																										
6	2011	ALL	Body	Theft Deterrent Module																																																										
6	2011	ALL	Body	Vehicle Comm. Interface Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																										
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																										
6	2012	ALL	Chassis	Electronic Brake Control Module																																																										
6	2012	ALL	Body	Body Control Module																																																										
6	2012	ALL	Body	Digital Radio Receiver																																																										
6	2012	ALL	Body	Generator Battery Control Module																																																										
6	2012	ALL	Body	Instrument Panel Cluster																																																										
6	2012	ALL	Body	Passenger Presence System																																																										
6	2012	ALL	Body	Personal Audio Link Module																																																										
6	2012	ALL	Body	Base Radio																																																										
6	2012	ALL	Body	Uplevel Radio																																																										
6	2012	ALL	Body	Supplemental Inflatable Restraint																																																										
6	2012	ALL	Body	Theft Deterrent Module																																																										
6	2012	ALL	Body	Vehicle Comm. Interface Module																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																										
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																										
6	2015	Canyon	Powertrain	Chassis Control Module																																																										
6	2015	Canyon	Powertrain	Transfer Case Control Module																														V																												
6	2015	Canyon	Chassis	Electronic Brake Control Module																																																										
6	2015	Canyon	Chassis	Power Steering Control Module																																																										
6	2015	Canyon	Body	Body Control Module																																																										
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
6	2015	Canyon	Body	Passenger Presence Module																																																										
6	2015	Canyon	Body	Radio																																																										
6	2015	Canyon	Body	Amplifier																																																										
6	2015	Canyon	Body	Human Machine Interface Control Module																																																										
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																																										
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																										
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																										
6	2015	Canyon	Body	Parking Assist Control Module																																																										
6	2015	Canyon	Body	Frontview Camera Module																																																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																										
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																											
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
6	2016	Canyon	Powertrain	Transfer Case Control Module																													V																														
6	2016	Canyon	Chassis	Electronic Brake Control Module																																																										
6	2016	Canyon	Chassis	Power Steering Control Module																																																										
6	2016	Canyon	Body	Body Control Module																																																										
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
6	2016	Canyon	Body	Passenger Presence Module																																																										
6	2016	Canyon	Body	Trailer Interface Control Module																																																										
6	2016	Canyon	Body	Radio																																																									
6	2016	Canyon	Body	Amplifier																																																									
6	2016	Canyon	Body	Human Machine Interface Control Module																																																									
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																																									
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																									
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																									
6	2016	Canyon	Body	Frontview Camera Module																																																									
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V													
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																														
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																														
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V													
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																														
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																									
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																							V	V	V	V			V	V										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																							V	V	V															
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																					
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2011	Express/Savana	Body	Body Control Module																																																									
7	2011	Express/Savana	Body	Digital Radio Receiver																																																									
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																									
7	2011	Express/Savana	Body	Passenger Presence System																																																									
7	2011	Express/Savana	Body	Radio																																																									
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
7	2011	Express/Savana	Body	Rollover Sensor																																																									
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
7	2011	Express/Savana	Body	Theft Deterrent Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V													
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																														
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																														
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V											
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																													
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																							
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																							
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																						
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																							V	V	V	V			V	V									
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																							V	V	V														
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																						
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																			
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																						
7	2011	Express Access/Savana Pro	Body	Body Control Module																																																						
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																						
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																						
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																						
7	2011	Express Access/Savana Pro	Body	Radio																																																						
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																						
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																						
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																						
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																						
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																						
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V											
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																													
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																						
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																												
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																						
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V											
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																												
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																						
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																						
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																						
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																						
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																							V	V	V	V			V	V									
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																							V	V	V														
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																						
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																			
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																						
7	2012	Express/Savana	Body	Body Control Module																																																						
7	2012	Express/Savana	Body	Digital Radio Receiver																																																						
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																						
7	2012	Express/Savana	Body	Passenger Presence System																																																						
7	2012	Express/Savana	Body	Radio																																																						
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																						
7	2012	Express/Savana	Body	Rollover Sensor																																																						
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																						
7	2012	Express/Savana	Body	Theft Deterrent Module																																																						
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																						
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V											
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																												
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																						
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V												
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																														
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																							V	V	V	V				V	V									
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																							V	V	V															
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																								
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																					
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2012	Express Access/Savana Pro	Body	Body Control Module																																																									
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																									
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																									
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																									
7	2012	Express Access/Savana Pro	Body	Radio																																																									
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																									
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																									
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																									
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																									
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V												
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																														
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																														
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																									
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																												V												
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																														
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																									
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																									
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																							V	V	V	V				V	V									
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																							V	V	V															
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																					
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																									
7	2013	Express/Savana	Body	Body Control Module																																																									
7	2013	Express/Savana	Body	Digital Radio Receiver																																																									
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																									
7	2013	Express/Savana	Body	Passenger Presence System																																																									
7	2013	Express/Savana	Body	Radio																																																									
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																									
7	2013	Express/Savana	Body	Rollover Sensor																																																									
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																									
7	2013	Express/Savana	Body	Theft Deterrent Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																									
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																												V												
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																														
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																									

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																																
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																											V														
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																							V	V	V	V				V	V										
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																							V	V	V																
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																									
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																					
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2013	Express Access/Savana Pro	Body	Body Control Module																																																										
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																										
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																										
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																										
7	2013	Express Access/Savana Pro	Body	Radio																																																										
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																										
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																										
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																										
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																										
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																										
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																										
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																										
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																										
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								V																		
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2014	Savana	Chassis	Electronic Brake Control Module																																																										
7	2014	Savana	Body	Body Control Module																																																										
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2014	Savana	Body	Passenger Presence Module																																																										
7	2014	Savana	Body	Rollover Sensor Module																																																										
7	2014	Savana	Body	Instrument Cluster																																																										
7	2014	Savana	Body	Chime Alarm Control Module																																																										
7	2014	Savana	Body	Base Radio																																																										
7	2014	Savana	Body	Navigation Radio																																																										
7	2014	Savana	Body	Uplevel Radio																																																										
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
7	2014	Savana	Body	Auxiliary Heater Control Module																																																										
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2014	Savana	Body	Parking Assist Control Module																																																										
7	2014	Savana	Body	Theft Deterrent Module																																																										
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2015	Savana	Chassis	Electronic Brake Control Module																																																										
7	2015	Savana	Body	Body Control Module																																																										
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2015	Savana	Body	Rollover Sensor Module																																																										
7	2015	Savana	Body	Instrument Cluster																																																										
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
7	2015	Savana	Body	Auxiliary Heater Control Module																																																										
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2015	Savana	Body	Parking Assist Control Module																																																										
7	2015	Savana	Body	Theft Deterrent Module																																																										
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2016	Savana	Chassis	Electronic Brake Control Module																																																										
7	2016	Savana	Body	Body Control Module																																																										
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2016	Savana	Body	Instrument Cluster																																																										
7	2016	Savana	Body	Chime Alarm Control Module																																																										
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
7	2016	Savana	Body	Auxiliary Heater Control Module																																																										
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2016	Savana	Body	Parking Assist Control Module																																																										
7	2016	Savana	Body	Theft Deterrent Module																																																										
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																														V												
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																								
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2011	Express/Savana	Body	Body Control Module																																																												
8	2011	Express/Savana	Body	Digital Radio Receiver																																																												
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																												
8	2011	Express/Savana	Body	Passenger Presence System																																																												
8	2011	Express/Savana	Body	Radio																																																												
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
8	2011	Express/Savana	Body	Rollover Sensor																																																												
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
8	2011	Express/Savana	Body	Theft Deterrent Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																																
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																																
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																								
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2011	Express Access/Savana Pro	Body	Body Control Module																																																												
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																												
8	2011	Express Access/Savana Pro	Body	Radio																																																												
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																												
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																																
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																																
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																																
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																								
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2012	Express/Savana	Body	Body Control Module																																																												
8	2012	Express/Savana	Body	Digital Radio Receiver																																																												
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																												
8	2012	Express/Savana	Body	Passenger Presence System																																																												
8	2012	Express/Savana	Body	Radio																																																												
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
8	2012	Express/Savana	Body	Rollover Sensor																																																										
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
8	2012	Express/Savana	Body	Theft Deterrent Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																													V													
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																						
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																										
8	2012	Express Access/Savana Pro	Body	Radio																																																										
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																													V													
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES				V																																																						
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
8	2013	Express/Savana	Body	Body Control Module																																																										
8	2013	Express/Savana	Body	Digital Radio Receiver																																																										
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
8	2013	Express/Savana	Body	Navigation Radio																																																										
8	2013	Express/Savana	Body	Park Assist Module																																																										
8	2013	Express/Savana	Body	Passenger Presence System																																																										
8	2013	Express/Savana	Body	Radio																																																										
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
8	2013	Express/Savana	Body	Rollover Sensor																																																										
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
8	2013	Express/Savana	Body	Theft Deterrent Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module									V	V	V																																															
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module									V	V	V																																															
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																													V													
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module									V	V	V																																															

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES				V																																																								
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2013	Express Access/Savana Pro	Body	Body Control Module																																																												
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																												
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																																												
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																												
8	2013	Express Access/Savana Pro	Body	Radio																																																												
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																												
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																																												
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																									V																		
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
8	2014	Savana	Chassis	Electronic Brake Control Module																																																												
8	2014	Savana	Body	Body Control Module																																																												
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
8	2014	Savana	Body	Passenger Presence Module																																																												
8	2014	Savana	Body	Rollover Sensor Module																																																												
8	2014	Savana	Body	Instrument Cluster																																																												
8	2014	Savana	Body	Chime Alarm Control Module																																																												
8	2014	Savana	Body	Base Radio																																																												
8	2014	Savana	Body	Navigation Radio																																																												
8	2014	Savana	Body	Uplevel Radio																																																												
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																												
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																												
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																												
8	2014	Savana	Body	Auxiliary Heater Control Module																																																												
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																												
8	2014	Savana	Body	Parking Assist Control Module																																																												
8	2014	Savana	Body	Theft Deterrent Module																																																												
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								V																	
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
8	2015	Savana	Chassis	Electronic Brake Control Module																																																									
8	2015	Savana	Body	Body Control Module																																																									
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
8	2015	Savana	Body	Rollover Sensor Module																																																									
8	2015	Savana	Body	Instrument Cluster																																																									
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																									
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																									
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																									
8	2015	Savana	Body	Auxiliary Heater Control Module																																																									
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																									
8	2015	Savana	Body	Parking Assist Control Module																																																									
8	2015	Savana	Body	Theft Deterrent Module																																																									
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																									
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																									
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																									
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																									
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																									
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																									
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								V																	
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																									
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																									
8	2016	Savana	Chassis	Electronic Brake Control Module																																																									
8	2016	Savana	Body	Body Control Module																																																									
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																									
8	2016	Savana	Body	Instrument Cluster																																																									
8	2016	Savana	Body	Chime Alarm Control Module																																																									
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																									
8	2016	Savana	Body	Telematics Communication Interface Control Module																																																									
8	2016	Savana	Body	Auxiliary Heater Control Module																																																									
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																									
8	2016	Savana	Body	Parking Assist Control Module																																																									
8	2016	Savana	Body	Theft Deterrent Module																																																									
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																									
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																									
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																									
ALL	2004	ALL	Chassis	ABS																																																								
ALL	2004	ALL	Chassis	Air Suspension																																																								
ALL	2004	ALL	Body	Amplifier (Bose)																																																								
ALL	2004	ALL	Body	Body Control Module																																																								
ALL	2004	ALL	Body	Digital Radio Receiver																																																								
ALL	2004	ALL	Body	Driver Door Module																																																								
ALL	2004	ALL	Body	Driver Seat Module																																																								
ALL	2004	ALL	Body	Heating and Air Conditioning																																																								
ALL	2004	ALL	Body	Instrument Panel Cluster																																																								
ALL	2004	ALL	Body	OnStar																																																								
ALL	2004	ALL	Body	Passenger Door Module																																																								

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
ALL	2004	ALL	Body	Uplevel Radio																																																												
ALL	2004	ALL	Body	Navigation Radio																																																												
ALL	2004	ALL	Body	Rear Seat Audio																																																												
ALL	2004	ALL	Body	Supplemental Inflatable Restraint		V																																																										
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																												
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																												
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																												
ALL	2005	ALL	Chassis	ABS																																																												
ALL	2005	ALL	Chassis	Air Suspension																																																												
ALL	2005	ALL	Body	Body Control Module																																																												
ALL	2005	ALL	Body	Digital Radio Receiver																																																												
ALL	2005	ALL	Body	Driver Door Module (SUV)																																																												
ALL	2005	ALL	Body	Driver Door Module (SUT)																																																												
ALL	2005	ALL	Body	Driver Seat Module																																																												
ALL	2005	ALL	Body	Heating and Air Conditioning																																																												
ALL	2005	ALL	Body	Instrument Panel Cluster																																																												
ALL	2005	ALL	Body	Passenger Door Module																																																												
ALL	2005	ALL	Body	Uplevel Radio																																																												
ALL	2005	ALL	Body	Navigation Radio																																																												
ALL	2005	ALL	Body	Rear Seat Audio																																																												
ALL	2005	ALL	Body	Supplemental Inflatable Restraint		V																																																										
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																												
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																												
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																												
ALL	2006	H2	Chassis	ABS																																																												
ALL	2006	H2	Chassis	Air Suspension																																																												
ALL	2006	H2	Body	Body Control Module																																																												
ALL	2006	H2	Body	Digital Radio Receiver																																																												
ALL	2006	H2	Body	Driver Door Module (SUV)																																																												
ALL	2006	H2	Body	Driver Door Module (SUT)																																																												
ALL	2006	H2	Body	Driver Seat Module																																																												
ALL	2006	H2	Body	Heating and Air Conditioning																																																												
ALL	2006	H2	Body	Instrument Panel Cluster																																																												
ALL	2006	H2	Body	Passenger Door Module																																																												
ALL	2006	H2	Body	Uplevel Radio																																																												
ALL	2006	H2	Body	Navigation Radio																																																												
ALL	2006	H2	Body	Rear Seat Audio																																																												
ALL	2006	H2	Body	Supplemental Inflatable Restraint			V																																																								
ALL	2006	H3	Powertrain	Engine Control Module																																																												
ALL	2006	H3	Powertrain	Transmission Control Module																																																												
ALL	2006	H3	Powertrain	Transfer Case Control Module																																																												
ALL	2006	H3	Chassis	Antilock Brake System																																																												
ALL	2006	H3	Body	Body Control Module																																																												
ALL	2006	H3	Body	Digital Radio Receiver																																																												
ALL	2006	H3	Body	Instrument Panel Cluster																																																												
ALL	2006	H3	Body	Uplevel Radio																																																												
ALL	2006	H3	Body	Navigation Radio																																																												
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																																												
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																												
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																												
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
ALL	2007	H2	Chassis	ABS																																																												
ALL	2007	H2	Chassis	Air Suspension																																																												
ALL	2007	H2	Body	Amplifier (Bose)																																																												
ALL	2007	H2	Body	Body Control Module																																																												
ALL	2007	H2	Body	Digital Radio Receiver																																																												
ALL	2007	H2	Body	Driver Door Module (SUV)																																																												
ALL	2007	H2	Body	Driver Door Module (SUT)																																																												
ALL	2007	H2	Body	Driver Seat Module																																																												
ALL	2007	H2	Body	HVAC Control Module																																																												
ALL	2007	H2	Body	Instrument Panel Cluster																																																												
ALL	2007	H2	Body	Passenger Door Module																																																												
ALL	2007	H2	Body	Uplevel Radio																																																												
ALL	2007	H2	Body	Navigation Radio																																																												
ALL	2007	H2	Body	Rear Seat Audio																																																												
ALL	2007	H2	Body	Supplemental Inflatable Restraint			V																																																								
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																																												
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																												
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																												
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																												
ALL	2007	H3	Chassis	EBCM																																																												
ALL	2007	H3	Body	Body Control Module (5GT)																																																												
ALL	2007	H3	Body	Body Control Module (ADM)																																																												
ALL	2007	H3	Body	Digital Radio Receiver																																																												
ALL	2007	H3	Body	Generator Battery Control Module																																																												
ALL	2007	H3	Body	Instrument Panel Cluster																																																												
ALL	2007	H3	Body	Personal Audio Link Module																																																												
ALL	2007	H3	Body	Uplevel Radio																																																												
ALL	2007	H3	Body	Navigation Radio																																																												
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																																												
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																												
ALL	2008	H2	Chassis	Air SCM																																																												
ALL	2008	H2	Chassis	EBCM																																																												
ALL	2008	H2	Body	Amplifier (Bose)																																																												
ALL	2008	H2	Body	Body Control Module																																																												
ALL	2008	H2	Body	Digital Radio Receiver																																																												
ALL	2008	H2	Body	Driver Door Switch																																																												
ALL	2008	H2	Body	HVAC Control Module						V																																																						
ALL	2008	H2	Body	Instrument Panel Cluster																																																												
ALL	2008	H2	Body	Memory Seat Module							V																																																				
ALL	2008	H2	Body	Passenger Door Switch																																																												
ALL	2008	H2	Body	Radio																																																											
ALL	2008	H2	Body	Rear Heated Seat Module																																																												
ALL	2008	H2	Body	Rear HVAC/RSA																																																												
ALL	2008	H2	Body	Rollover Sensor																																																												
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																																												
ALL	2008	H2	Body	Theft Deterrent Module																																																												
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																																												

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)																																																											
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																											
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																												
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																												
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module																																																												
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																												
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																																												
ALL	2008	H3	Chassis	EBCM																																																												
ALL	2008	H3	Body	Body Control Module (5GT)																																																												
ALL	2008	H3	Body	Body Control Module (ADM)																																																												
ALL	2008	H3	Body	Digital Radio Receiver																																																												
ALL	2008	H3	Body	Generator Battery Control Module																																																												
ALL	2008	H3	Body	Instrument Panel Cluster																																																												
ALL	2008	H3	Body	Personal Audio Link Module																																																												
ALL	2008	H3	Body	Uplevel Radio																																																												
ALL	2008	H3	Body	Navigation Radio																																																												
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																																												
ALL	2008	H3	Body	Theft Deterrent Module																																																												
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																																												
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																												
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																												
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																												
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																												
ALL	2009	H2	Chassis	Air SCM																																																												
ALL	2009	H2	Chassis	EBCM																																																												
ALL	2009	H2	Body	Amplifier (Bose)																																																												
ALL	2009	H2	Body	Body Control Module																																																												
ALL	2009	H2	Body	Digital Radio Receiver																																																												
ALL	2009	H2	Body	Driver Door Switch																																																												
ALL	2009	H2	Body	HVAC Control Module						V																																																					
ALL	2009	H2	Body	Instrument Panel Cluster																																																												
ALL	2009	H2	Body	Memory Seat Module							V																																																				
ALL	2009	H2	Body	Passenger Door Switch																																																												
ALL	2009	H2	Body	Radio																																																											
ALL	2009	H2	Body	Rear Heated Seat Module																																																												
ALL	2009	H2	Body	Rear HVAC/RSA																																																												
ALL	2009	H2	Body	Rollover Sensor																																																												
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																																												
ALL	2009	H2	Body	Theft Deterrent Module																																																												
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																												
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																												
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)																																																											
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																											
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																											
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																											
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																											
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																											
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)																																																											
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)																																																											
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																											
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																											

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2009	H3	Chassis	EBCM																																																										
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																																										
ALL	2009	H3	Body	Body Control Module (ADM)																																																										
ALL	2009	H3	Body	Digital Radio Receiver																																																										
ALL	2009	H3	Body	Generator Battery Control Module																																																										
ALL	2009	H3	Body	Instrument Panel Cluster																																																										
ALL	2009	H3	Body	Personal Audio Link Module																																																										
ALL	2009	H3	Body	Uplevel Radio																																																										
ALL	2009	H3	Body	Navigation Radio																																																										
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																																										
ALL	2009	H3	Body	Theft Deterrent Module																																																										
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module											V	V																																														
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																										
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																										
ALL	2010	H2	Chassis	Air SCM																																																										
ALL	2010	H2	Chassis	EBCM																																																										
ALL	2010	H2	Body	Amplifier (Bose)																																																										
ALL	2010	H2	Body	Body Control Module																																																										
ALL	2010	H2	Body	Digital Radio Receiver																																																										
ALL	2010	H2	Body	Driver Door Switch																																																										
ALL	2010	H2	Body	HVAC Control Module						V																																										V										
ALL	2010	H2	Body	Instrument Panel Cluster																																																										
ALL	2010	H2	Body	Memory Seat Module							V																																																			
ALL	2010	H2	Body	Passenger Door Switch																																																										
ALL	2010	H2	Body	Personal Audio Link Module																																																										
ALL	2010	H2	Body	Radio																																																										
ALL	2010	H2	Body	Rear Heated Seat Module																																																										
ALL	2010	H2	Body	Rear HVAC/RSA																																																										
ALL	2010	H2	Body	Rollover Sensor																																																										
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																																										
ALL	2010	H2	Body	Theft Deterrent Module																																																										
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																V										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																																V										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																																										
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																																										
ALL	2010	H3	Chassis	EBCM																																																										
ALL	2010	H3	Body	Body Control Module																																																										
ALL	2010	H3	Body	Digital Radio Receiver																																																										
ALL	2010	H3	Body	Generator Battery Control Module																																																										
ALL	2010	H3	Body	Instrument Panel Cluster																																																										

Engine type	Year	Model	System 1	System 2	Calibrate HVAC Module	Clear Manufacturer Enable Counter	Buckle Up Reminder	Data List	Brake Press. Sen. Calibration	Actuator Recalibration	Adj. Pedals Info.	Alarm Data	EngineData	AutoTransmissionData	HO2S DATA	AutoTransmission Data	Automatic Level Control Test	Damper Actuator Test	Lumbar Info. (if equipped)	Adjustable Pedal Calibration	Error Conditions	Horizontal Motor	Recline Motor	Rotation Motor	Auto. Calibration	Adjustable Pedals Softstops Learn	Trailer Brake Control Data	Assist Step Motor Learn	Parking Assist System Data	Active Grille Air Shutter 1	Active Grille Air Shutter 2	Automatic Level Control Data	Range Actuator Lock	Clear Driver-Specific Steering Angles	Clear Softstops	Engine Data Display	Transmission Data Display	Reduction of Pressure Drive	HPCM Data	Engine Auto-Stop Data	Service Charge	Fuel System	Garage Shift Adapt. Data	TC Data	Injector Display and Reprogram	Copy GPCM Inj. Flow Rates to ECM	Copy ECM Inj. Flow Rates to GPCM	TC Learn	5-6 Adapt. Data	Preset Transmission Adapts.	HVAC Ambient temperature display	Electrical / Theft Data	Exh Aftertreatment Data	Intake Air Heater Data	Hybrid Data	Tac Data	BECM Data	Contactor Open Reasons	Hybrid Trans. Data	Autostart Entry Reasons
ALL	2010	H3	Body	Personal Audio Link Module																																																																
ALL	2010	H3	Body	Uplevel Radio																																																																
ALL	2010	H3	Body	Navigation Radio																																																																
ALL	2010	H3	Body	Supplemental Inflatable Restraint																																																																
ALL	2010	H3	Body	Theft Deterrent Module																																																																
ALL	2010	H3	Body	Vehicle Comm. Interface Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																												
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																																												
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																												
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																												
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																												
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																												
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2004	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
C	2004	ALL	Chassis	ESC																																																											
C	2004	ALL	Chassis	Rear Wheel Steering																																																												
C	2004	ALL	Chassis	Tire Pressure Monitor																																																												
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2004	ALL	Chassis	VSES																																																											
C	2004	ALL	Body	Amplifier (Bose)																																																												
C	2004	ALL	Body	Body Control Module																																																											
C	2004	ALL	Body	CD Changer																																																											
C	2004	ALL	Body	Chime																																																											
C	2004	ALL	Body	Driver Door Module																																																											
C	2004	ALL	Body	Driver Seat Module																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto																																																											
C	2004	ALL	Body	Heating and Air Conditioning Manual																																																											
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																											
C	2004	ALL	Body	Instrument Panel Cluster																																																											
C	2004	ALL	Body	OnStar																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2004	ALL	Body	Passenger Door Module																																																												
C	2004	ALL	Body	Passenger Presence System																																																												
C	2004	ALL	Body	Radio Base																																																												
C	2004	ALL	Body	Radio Uplevel																																																												
C	2004	ALL	Body	Radio Navigation																																																												
C	2004	ALL	Body	Rear Aux. Climate Module																																																												
C	2004	ALL	Body	Rear HVAC																																																												
C	2004	ALL	Body	Rear Seat Audio																																																												
C	2004	ALL	Body	Rear Seat Entertainment																																																												
C	2004	ALL	Body	Supplemental Inflatable Restraint																																																												
C	2004	ALL	Body	Vehicle Theft Deterrent																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																												
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																												
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																												
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																												
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																												
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																												
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																												
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																												
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
C	2005	ALL	Chassis	ABS Over 8600 GVW																																																												
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
C	2005	ALL	Chassis	ESC																																																											
C	2005	ALL	Chassis	Rear Wheel Steering																																																												
C	2005	ALL	Chassis	Tire Pressure Monitor																																																												
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																																												
C	2005	ALL	Chassis	VSES																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2005	ALL	Body	Amplifier (Bose)																																																												
C	2005	ALL	Body	Body Control Module																																																													
C	2005	ALL	Body	CD Changer																																																													
C	2005	ALL	Body	Chime																																																													
C	2005	ALL	Body	Disc Player and Video Display																																																														
C	2005	ALL	Body	Driver Door Module																																																														
C	2005	ALL	Body	Driver Seat Module																																																														
C	2005	ALL	Body	Generator Battery Control Module																																																														
C	2005	ALL	Body	Heating and Air Conditioning Auto																																																														
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																														
C	2005	ALL	Body	Heating and Air Conditioning Manual																																																														
C	2005	ALL	Body	Instrument Panel Cluster																																																														
C	2005	ALL	Body	Passenger Door Module																																																														
C	2005	ALL	Body	Passenger Presence System																																																														
C	2005	ALL	Body	Base Radio																																																														
C	2005	ALL	Body	Uplevel Radio																																																														
C	2005	ALL	Body	Navigation Radio																																																														
C	2005	ALL	Body	Rear Aux. Climate Module																																																														
C	2005	ALL	Body	Rear HVAC																																																														
C	2005	ALL	Body	Rear Seat Audio																																																														
C	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
C	2005	ALL	Body	Vehicle Comm. Interface Module																																																														
C	2005	ALL	Body	Vehicle Theft Deterrent																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																														
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																														
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																														
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																														
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																														
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																														
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																														
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																											
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																											
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																											
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																											
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																											
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																											
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																											
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																											
C	2006	ALL	Chassis	ABS Over 8600 GVW																																																											
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																											
C	2006	ALL	Chassis	ESC																																																										
C	2006	ALL	Chassis	Tire Pressure Monitor																																																											
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																																											
C	2006	ALL	Chassis	VSES																																																										
C	2006	ALL	Body	Amplifier (Bose)																																																											
C	2006	ALL	Body	Body Control Module																																																										
C	2006	ALL	Body	CD Changer																																																										
C	2006	ALL	Body	Chime																																																										
C	2006	ALL	Body	Disc Player and Video Display																																																										
C	2006	ALL	Body	Driver Door Module																																																										
C	2006	ALL	Body	Driver Seat Module																																																										
C	2006	ALL	Body	Generator Battery Control Module																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto																																																										
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
C	2006	ALL	Body	Heating and Air Conditioning Manual																																																										
C	2006	ALL	Body	Instrument Panel Cluster																																																										
C	2006	ALL	Body	Passenger Door Module																																																										
C	2006	ALL	Body	Passenger Presence System																																																										
C	2006	ALL	Body	Base Radio																																																										
C	2006	ALL	Body	Uplevel Radio																																																										
C	2006	ALL	Body	Navigation Radio																																																										
C	2006	ALL	Body	Rear Aux. Climate Module																																																										
C	2006	ALL	Body	Rear HVAC																																																										
C	2006	ALL	Body	Rear Seat Audio																																																										
C	2006	ALL	Body	Supplemental Inflatable Restraint																																																										
C	2006	ALL	Body	Vehicle Theft Deterrent																																																										
C	2006	ALL	Body	Vehicle Comm. Interface Module																																																										
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																													
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																													
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																													
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																													
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																													
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2007	Sierra	Chassis	Electronic Suspension Control																																																													
C	2007	Sierra	Chassis	Trailer Brake Control Module																																																													
C	2007	Sierra	Body	Amplifier (Bose)																																																													
C	2007	Sierra	Body	Body Control Module																																																													
C	2007	Sierra	Body	Body Control Module (aux.)																																																													
C	2007	Sierra	Body	Digital Radio Receiver																																																													
C	2007	Sierra	Body	Driver Door Switch																																																													
C	2007	Sierra	Body	HVAC Control Module Auto																																																													
C	2007	Sierra	Body	HVAC Control Module Manual																																																													
C	2007	Sierra	Body	Instrument Panel Cluster																																																													
C	2007	Sierra	Body	Memory Seat Module																																																													
C	2007	Sierra	Body	Park Assist Module																																																													
C	2007	Sierra	Body	Passenger Door Switch																																																													
C	2007	Sierra	Body	Passenger Presence System																																																													
C	2007	Sierra	Body	Radio																																																												
C	2007	Sierra	Body	Rear Heated Seat Module																																																													
C	2007	Sierra	Body	Rear HVAC/RSA																																																													
C	2007	Sierra	Body	Rollover Sensor																																																													
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																																													
C	2007	Sierra	Body	Theft Deterrent Module																																																													
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																													
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																													
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2007	Yukon	Chassis	Electronic Suspension Control																																																													
C	2007	Yukon	Chassis	Trailer Brake Control Module																																																													
C	2007	Yukon	Body	Amplifier (Bose)																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2007	Yukon	Body	Assist Step Controller																																																															
C	2007	Yukon	Body	Body Control Module																																																															
C	2007	Yukon	Body	Body Control Module (aux.)																																																															
C	2007	Yukon	Body	Digital Radio Receiver																																																															
C	2007	Yukon	Body	Driver Door Switch																																																															
C	2007	Yukon	Body	HVAC Control Module Auto																																																															
C	2007	Yukon	Body	HVAC Control Module Manual																																																															
C	2007	Yukon	Body	Instrument Panel Cluster																																																															
C	2007	Yukon	Body	Lift Gate Module																																																															
C	2007	Yukon	Body	Memory Seat Module																																																															
C	2007	Yukon	Body	Park Assist Module																																																															
C	2007	Yukon	Body	Passenger Door Switch																																																															
C	2007	Yukon	Body	Passenger Presence System																																																															
C	2007	Yukon	Body	Radio																																																															
C	2007	Yukon	Body	Rear Heated Seat Module																																																															
C	2007	Yukon	Body	Rear HVAC/RSA																																																															
C	2007	Yukon	Body	Rollover Sensor																																																															
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																																															
C	2007	Yukon	Body	Theft Deterrent Module																																																															
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																															
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																															
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																															
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																															
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																															
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																															
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																															
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																															
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																															
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																															
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																															
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																															
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																															
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																															
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																															
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																																															
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																															
C	2007	Yukon XL	Body	Amplifier (Bose)																																																															
C	2007	Yukon XL	Body	Assist Step Controller																																																															
C	2007	Yukon XL	Body	Body Control Module																																																															
C	2007	Yukon XL	Body	Body Control Module (aux.)																																																															
C	2007	Yukon XL	Body	Digital Radio Receiver																																																															
C	2007	Yukon XL	Body	Driver Door Switch																																																															
C	2007	Yukon XL	Body	HVAC Control Module Auto																																																															
C	2007	Yukon XL	Body	HVAC Control Module Manual																																																															
C	2007	Yukon XL	Body	Instrument Panel Cluster																																																															
C	2007	Yukon XL	Body	Lift Gate Module																																																															
C	2007	Yukon XL	Body	Memory Seat Module																																																															
C	2007	Yukon XL	Body	Park Assist Module																																																															
C	2007	Yukon XL	Body	Passenger Door Switch																																																															
C	2007	Yukon XL	Body	Passenger Presence System																																																															
C	2007	Yukon XL	Body	Radio																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2007	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2007	Yukon XL	Body	Rear HVAC/RSA																																																													
C	2007	Yukon XL	Body	Rollover Sensor																																																													
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																													
C	2007	Yukon XL	Body	Theft Deterrent Module																																																													
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																													
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																													
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																													
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																													
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																													
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																													
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																													
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																													
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																													
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																													
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																													
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																													
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																													
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																													
C	2008	Sierra	Chassis	Electronic Suspension Control																																																													
C	2008	Sierra	Chassis	Trailer Brake Control Module																																																													
C	2008	Sierra	Body	Amplifier (Bose)																																																													
C	2008	Sierra	Body	Body Control Module																																																													
C	2008	Sierra	Body	Body Control Module (aux.)																																																													
C	2008	Sierra	Body	Digital Radio Receiver																																																													
C	2008	Sierra	Body	Driver Door Switch																																																													
C	2008	Sierra	Body	HVAC Control Module Auto																																																													
C	2008	Sierra	Body	HVAC Control Module Manual																																																													
C	2008	Sierra	Body	Instrument Panel Cluster																																																													
C	2008	Sierra	Body	Memory Seat Module																																																													
C	2008	Sierra	Body	Park Assist Module																																																													
C	2008	Sierra	Body	Passenger Door Switch																																																													
C	2008	Sierra	Body	Passenger Presence System																																																													
C	2008	Sierra	Body	Radio																																																													
C	2008	Sierra	Body	Rear Heated Seat Module																																																													
C	2008	Sierra	Body	Rear HVAC/RSA																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2008	Sierra	Body	Rollover Sensor																																																												
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2008	Sierra	Body	Theft Deterrent Module																																																												
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Yukon	Chassis	Electronic Brake Control Module																																																												
C	2008	Yukon	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon	Body	Amplifier (Bose)																																																												
C	2008	Yukon	Body	Assist Step Controller																																																												
C	2008	Yukon	Body	Body Control Module																																																												
C	2008	Yukon	Body	Body Control Module (aux.)																																																												
C	2008	Yukon	Body	Digital Radio Receiver																																																												
C	2008	Yukon	Body	Driver Door Switch																																																												
C	2008	Yukon	Body	HVAC Control Module Auto																																																												
C	2008	Yukon	Body	HVAC Control Module Manual																																																												
C	2008	Yukon	Body	Instrument Panel Cluster																																																												
C	2008	Yukon	Body	Lift Gate Module																																																												
C	2008	Yukon	Body	Memory Seat Module																																																												
C	2008	Yukon	Body	Park Assist Module																																																												
C	2008	Yukon	Body	Passenger Door Switch																																																												
C	2008	Yukon	Body	Passenger Presence System																																																												
C	2008	Yukon	Body	Radio																																																												
C	2008	Yukon	Body	Rear Heated Seat Module																																																												
C	2008	Yukon	Body	Rear HVAC/RSA																																																												
C	2008	Yukon	Body	Rollover Sensor																																																												
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon	Body	Theft Deterrent Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																										
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module				V																																																								
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																											
C	2008	Yukon Hybrid	Body	Body Control Module																																																												
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																												
C	2008	Yukon Hybrid	Body	Driver Door Switch																																																												
C	2008	Yukon Hybrid	Body	HVAC Control Module																																																												
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
C	2008	Yukon Hybrid	Body	Lift Gate Module																																																												
C	2008	Yukon Hybrid	Body	Memory Seat Module																																																												
C	2008	Yukon Hybrid	Body	Park Assist Module																																																												
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																																												
C	2008	Yukon Hybrid	Body	Passenger Presence System																																																												
C	2008	Yukon Hybrid	Body	Radio																																																												
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
C	2008	Yukon Hybrid	Body	Rollover Sensor																																																												
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2008	Yukon XL	Body	Amplifier (Bose)																																																												
C	2008	Yukon XL	Body	Assist Step Controller																																																												
C	2008	Yukon XL	Body	Body Control Module																																																												
C	2008	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2008	Yukon XL	Body	Digital Radio Receiver																																																												
C	2008	Yukon XL	Body	Driver Door Switch																																																												
C	2008	Yukon XL	Body	HVAC Control Module Auto																																																												
C	2008	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2008	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2008	Yukon XL	Body	Lift Gate Module																																																												
C	2008	Yukon XL	Body	Memory Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2008	Yukon XL	Body	Park Assist Module																																																														
C	2008	Yukon XL	Body	Passenger Door Switch																																																														
C	2008	Yukon XL	Body	Passenger Presence System																																																														
C	2008	Yukon XL	Body	Radio																																																														
C	2008	Yukon XL	Body	Rear Heated Seat Module																																																														
C	2008	Yukon XL	Body	Rear HVAC/RSA																																																														
C	2008	Yukon XL	Body	Rollover Sensor																																																														
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																														
C	2008	Yukon XL	Body	Theft Deterrent Module																																																														
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																														
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																																									
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual					V																																																									
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																														
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																														
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																														
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																														
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																														
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual																																																														
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																														
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																														
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																														
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																														
C	2009	Sierra	Chassis	Electronic Suspension Control																																																														
C	2009	Sierra	Chassis	Trailer Brake Control Module																																																														
C	2009	Sierra	Body	Amplifier (Bose)																																																														
C	2009	Sierra	Body	Body Control Module																																																														
C	2009	Sierra	Body	Body Control Module (aux.)																																																														
C	2009	Sierra	Body	Digital Radio Receiver																																																														
C	2009	Sierra	Body	Driver Door Switch																																																														
C	2009	Sierra	Body	HVAC Control Module Auto																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2009	Sierra	Body	HVAC Control Module Manual																																																														
C	2009	Sierra	Body	Instrument Panel Cluster																																																														
C	2009	Sierra	Body	Memory Seat Module																																																														
C	2009	Sierra	Body	Park Assist Module																																																														
C	2009	Sierra	Body	Passenger Door Switch																																																														
C	2009	Sierra	Body	Passenger Presence System																																																														
C	2009	Sierra	Body	Radio																																																														
C	2009	Sierra	Body	Rear Heated Seat Module																																																														
C	2009	Sierra	Body	Rear HVAC/RSA																																																														
C	2009	Sierra	Body	Rollover Sensor																																																														
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																																														
C	2009	Sierra	Body	Theft Deterrent Module																																																														
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																															
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																															
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																															
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																															
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																												
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																														
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																														
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																														
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																														
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																														
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module				V																																																										
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																														
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																														
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																														
C	2009	Sierra Hybrid	Body	Body Control Module																																																														
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																														
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																														
C	2009	Sierra Hybrid	Body	Driver Door Switch																																																														
C	2009	Sierra Hybrid	Body	HVAC Control Module																																																														
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																														
C	2009	Sierra Hybrid	Body	Memory Seat Module																																																														
C	2009	Sierra Hybrid	Body	Park Assist Module																																																														
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																																														
C	2009	Sierra Hybrid	Body	Passenger Presence System																																																														
C	2009	Sierra Hybrid	Body	Radio																																																														
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																														
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																														
C	2009	Sierra Hybrid	Body	Rollover Sensor																																																														
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																														
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																														
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																														
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed																																																														
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed																																																														
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																														
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																														
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																														
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																														
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
C	2009	Yukon	Chassis	Electronic Brake Control Module																																																													
C	2009	Yukon	Chassis	Electronic Suspension Control																																																													
C	2009	Yukon	Chassis	Trailer Brake Control Module																																																													
C	2009	Yukon	Body	Amplifier (Bose)																																																													
C	2009	Yukon	Body	Assist Step Controller																																																													
C	2009	Yukon	Body	Body Control Module																																																													
C	2009	Yukon	Body	Body Control Module (aux.)																																																													
C	2009	Yukon	Body	Digital Radio Receiver																																																													
C	2009	Yukon	Body	Driver Door Switch																																																													
C	2009	Yukon	Body	HVAC Control Module Auto																																																													
C	2009	Yukon	Body	HVAC Control Module Manual																																																													
C	2009	Yukon	Body	Instrument Panel Cluster																																																													
C	2009	Yukon	Body	Left Side Object Detection Module																																																													
C	2009	Yukon	Body	Lift Gate Module																																																													
C	2009	Yukon	Body	Memory Seat Module																																																													
C	2009	Yukon	Body	Park Assist Module																																																													
C	2009	Yukon	Body	Passenger Door Switch																																																													
C	2009	Yukon	Body	Passenger Presence System																																																													
C	2009	Yukon	Body	Radio																																																													
C	2009	Yukon	Body	Rear Heated Seat Module																																																													
C	2009	Yukon	Body	Rear HVAC/RSA																																																													
C	2009	Yukon	Body	Right Side Object Detection Module																																																													
C	2009	Yukon	Body	Rollover Sensor																																																													
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																																													
C	2009	Yukon	Body	Theft Deterrent Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																											
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																													
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																													
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																													
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module				V																																																								
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																													
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																													
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																													
C	2009	Yukon Hybrid	Body	Body Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																												
C	2009	Yukon Hybrid	Body	Driver Door Switch																																																												
C	2009	Yukon Hybrid	Body	Heated Seat Module																																																												
C	2009	Yukon Hybrid	Body	HVAC Control Module																																																												
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
C	2009	Yukon Hybrid	Body	Park Assist Module																																																												
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																																												
C	2009	Yukon Hybrid	Body	Passenger Presence System																																																												
C	2009	Yukon Hybrid	Body	Radio																																																												
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
C	2009	Yukon Hybrid	Body	Rollover Sensor																																																												
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																												
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																																						
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2009	Yukon XL	Body	Amplifier (Bose)																																																												
C	2009	Yukon XL	Body	Assist Step Controller																																																												
C	2009	Yukon XL	Body	Body Control Module																																																												
C	2009	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2009	Yukon XL	Body	Digital Radio Receiver																																																												
C	2009	Yukon XL	Body	Driver Door Switch																																																												
C	2009	Yukon XL	Body	HVAC Control Module Auto																																																												
C	2009	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2009	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2009	Yukon XL	Body	Left Side Object Detection Module																																																												
C	2009	Yukon XL	Body	Lift Gate Module																																																												
C	2009	Yukon XL	Body	Memory Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2009	Yukon XL	Body	Park Assist Module																																																											
C	2009	Yukon XL	Body	Passenger Door Switch																																																												
C	2009	Yukon XL	Body	Passenger Presence System																																																												
C	2009	Yukon XL	Body	Radio																																																												
C	2009	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2009	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2009	Yukon XL	Body	Right Side Object Detection Module																																																												
C	2009	Yukon XL	Body	Rollover Sensor																																																												
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2009	Yukon XL	Body	Theft Deterrent Module																																																												
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																												
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
C	2010	Sierra	Chassis	Electronic Suspension Control																																																												
C	2010	Sierra	Chassis	Trailer Brake Control Module																																																												
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra	Body	Amplifier (Bose)																																																												
C	2010	Sierra	Body	Body Control Module																																																											
C	2010	Sierra	Body	Body Control Module (aux.)																																																												
C	2010	Sierra	Body	Digital Radio Receiver																																																												
C	2010	Sierra	Body	Driver Door Switch																																																												
C	2010	Sierra	Body	HVAC Control Module Auto																																																												
C	2010	Sierra	Body	HVAC Control Module Manual																																																												
C	2010	Sierra	Body	Instrument Panel Cluster																																																												
C	2010	Sierra	Body	Memory Seat Module																																																												
C	2010	Sierra	Body	Park Assist Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2010	Sierra	Body	Passenger Door Switch																																																											
C	2010	Sierra	Body	Passenger Presence System																																																												
C	2010	Sierra	Body	Radio																																																												
C	2010	Sierra	Body	Rear Heated Seat Module																																																												
C	2010	Sierra	Body	Rear HVAC/RSA																																																												
C	2010	Sierra	Body	Supplemental Inflatable Restraint																																																												
C	2010	Sierra	Body	Theft Deterrent Module																																																												
C	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																												
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																												
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																												
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																											
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module				V																																																								
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																												
C	2010	Sierra Hybrid	Body	Body Control Module																																																												
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																												
C	2010	Sierra Hybrid	Body	Driver Door Switch																																																												
C	2010	Sierra Hybrid	Body	Heated Seat Module																																																												
C	2010	Sierra Hybrid	Body	HVAC Control Module																																																												
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
C	2010	Sierra Hybrid	Body	Park Assist Module																																																												
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																																												
C	2010	Sierra Hybrid	Body	Passenger Presence System																																																												
C	2010	Sierra Hybrid	Body	Radio																																																												
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																												
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Yukon	Chassis	Electronic Brake Control Module																																																												
C	2010	Yukon	Chassis	Electronic Suspension Control																																																												
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon	Body	Amplifier (Bose)																																																												
C	2010	Yukon	Body	Assist Step Controller																																																												
C	2010	Yukon	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2010	Yukon	Body	Body Control Module (aux.)																																																												
C	2010	Yukon	Body	Digital Radio Receiver																																																													
C	2010	Yukon	Body	Driver Door Switch																																																													
C	2010	Yukon	Body	HVAC Control Module Auto																																																													
C	2010	Yukon	Body	HVAC Control Module Manual																																																													
C	2010	Yukon	Body	Instrument Panel Cluster																																																													
C	2010	Yukon	Body	Left Side Object Detection Module																																																													
C	2010	Yukon	Body	Lift Gate Module																																																													
C	2010	Yukon	Body	Memory Seat Module																																																													
C	2010	Yukon	Body	Park Assist Module																																																													
C	2010	Yukon	Body	Passenger Door Switch																																																													
C	2010	Yukon	Body	Passenger Presence System																																																													
C	2010	Yukon	Body	Radio																																																													
C	2010	Yukon	Body	Rear Heated Seat Module																																																													
C	2010	Yukon	Body	Rear HVAC/RSA																																																													
C	2010	Yukon	Body	Right Side Object Detection Module																																																													
C	2010	Yukon	Body	Supplemental Inflatable Restraint																																																													
C	2010	Yukon	Body	Theft Deterrent Module																																																													
C	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																													
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																													
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																													
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																													
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																											
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																													
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																													
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																													
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																													
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																													
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																													
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module				V																																																								
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																													
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																													
C	2010	Yukon Hybrid	Body	Body Control Module																																																													
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																													
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																													
C	2010	Yukon Hybrid	Body	Driver Door Switch																																																													
C	2010	Yukon Hybrid	Body	Heated Seat Module																																																													
C	2010	Yukon Hybrid	Body	HVAC Control Module																																																													
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																													
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																													
C	2010	Yukon Hybrid	Body	Lift Gate Module																																																													
C	2010	Yukon Hybrid	Body	Park Assist Module																																																													
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																																													
C	2010	Yukon Hybrid	Body	Passenger Presence System																																																													
C	2010	Yukon Hybrid	Body	Radio																																																													
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																													
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																													
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																													
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																													
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																											
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																												
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																												
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																																												
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																												
C	2010	Yukon XL	Body	Amplifier (Bose)																																																												
C	2010	Yukon XL	Body	Assist Step Controller																																																												
C	2010	Yukon XL	Body	Body Control Module																																																												
C	2010	Yukon XL	Body	Body Control Module (aux.)																																																												
C	2010	Yukon XL	Body	Digital Radio Receiver																																																												
C	2010	Yukon XL	Body	Driver Door Switch																																																												
C	2010	Yukon XL	Body	HVAC Control Module Auto																																																												
C	2010	Yukon XL	Body	HVAC Control Module Manual																																																												
C	2010	Yukon XL	Body	Instrument Panel Cluster																																																												
C	2010	Yukon XL	Body	Left Side Object Detection Module																																																												
C	2010	Yukon XL	Body	Lift Gate Module																																																												
C	2010	Yukon XL	Body	Memory Seat Module																																																												
C	2010	Yukon XL	Body	Park Assist Module																																																												
C	2010	Yukon XL	Body	Passenger Door Switch																																																												
C	2010	Yukon XL	Body	Passenger Presence System																																																												
C	2010	Yukon XL	Body	Radio																																																												
C	2010	Yukon XL	Body	Rear Heated Seat Module																																																												
C	2010	Yukon XL	Body	Rear HVAC/RSA																																																												
C	2010	Yukon XL	Body	Right Side Object Detection Module																																																												
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
C	2010	Yukon XL	Body	Theft Deterrent Module																																																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																												
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																												
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																												
D	2008	ALL	Chassis	Electronic Brake Control Module																																																												
D	2008	ALL	Body	Body Control Module																																																												
D	2008	ALL	Body	Body Control Module (aux.)																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
D	2008	ALL	Body	Headlamp Control Module																																																											
D	2008	ALL	Body	HVAC Control Module Auto																																																												
D	2008	ALL	Body	Instrument Panel Cluster																																																												
D	2008	ALL	Body	Park Assist Module																																																												
D	2008	ALL	Body	Remote Control Door Lock Receiver																																																												
D	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
D	2008	ALL	Body	Theft Deterrent Module																																																												
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																												
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																												
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																												
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																												
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																												
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																												
D	2009	ALL	Chassis	Electronic Brake Control Module																																																												
D	2009	ALL	Body	Body Control Module																																																												
D	2009	ALL	Body	Body Control Module (aux.)																																																												
D	2009	ALL	Body	Headlamp Control Module																																																												
D	2009	ALL	Body	HVAC Control Module Auto																																																												
D	2009	ALL	Body	Instrument Panel Cluster																																																												
D	2009	ALL	Body	Park Assist Module																																																												
D	2009	ALL	Body	Remote Control Door Lock Receiver																																																												
D	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
D	2009	ALL	Body	Theft Deterrent Module																																																												
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																																												
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																																												
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																																												
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																																												
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																																												
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																																												
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																																												
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																																												
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																																												
D	2010	ALL	Chassis	Electronic Brake Control Module																																																												
D	2010	ALL	Body	Body Control Module																																																												
D	2010	ALL	Body	Body Control Module (aux.)																																																												
D	2010	ALL	Body	Headlamp Control Module																																																												
D	2010	ALL	Body	HVAC Control Module Auto																																																												
D	2010	ALL	Body	Instrument Panel Cluster																																																												
D	2010	ALL	Body	Park Assist Module																																																												
D	2010	ALL	Body	Remote Control Door Lock Receiver																																																												
D	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																												
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2004	Express/Savana	Chassis	VSES																																																										
G	2004	Express/Savana	Body	Body Control Module																																																										
G	2004	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2004	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2004	Express/Savana	Body	OnStar																																																										
G	2004	Express/Savana	Body	Base Radio																																																										
G	2004	Express/Savana	Body	Uplevel Radio																																																										
G	2004	Express/Savana	Body	Remote Function Actuation																																																										
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2004	Express Access/Savana Pro	Chassis	VSES																																																										
G	2004	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2004	Express Access/Savana Pro	Body	OnStar																																																										
G	2004	Express Access/Savana Pro	Body	Base Radio																																																										
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2005	Express/Savana	Chassis	VSES																																																										
G	2005	Express/Savana	Body	Body Control Module																																																										
G	2005	Express/Savana	Body	Instrument Panel Cluster																																							V																			
G	2005	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2005	Express/Savana	Body	Base Radio																																																										
G	2005	Express/Savana	Body	Uplevel Radio																																																										
G	2005	Express/Savana	Body	Remote Function Actuation																																																										
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2005	Express Access/Savana Pro	Chassis	VSES																																																										
G	2005	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																							V																			
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2005	Express Access/Savana Pro	Body	Base Radio																																																										
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																																										
G	2006	Express/Savana	Chassis	VSES																																																										
G	2006	Express/Savana	Body	Body Control Module																																																										
G	2006	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2006	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2006	Express/Savana	Body	Passenger Presence System																																																										
G	2006	Express/Savana	Body	Base Radio																																																										
G	2006	Express/Savana	Body	Uplevel Radio																																																										
G	2006	Express/Savana	Body	Remote Function Actuation																																																										
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																										
G	2006	Express Access/Savana Pro	Chassis	VSES																																																										
G	2006	Express Access/Savana Pro	Body	Body Control Module																																																										
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																										
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																										
G	2006	Express Access/Savana Pro	Body	Base Radio																																																										
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																										
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																										
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																										
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
G	2007	Express/Savana	Body	Body Control Module																																																										
G	2007	Express/Savana	Body	Instrument Panel Cluster																																																										
G	2007	Express/Savana	Body	Multifunction Alarm Module																																																										
G	2007	Express/Savana	Body	Passenger Presence System																																																										
G	2007	Express/Savana	Body	Base Radio																																																										
G	2007	Express/Savana	Body	Uplevel Radio																																																										
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																																											
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																																											
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2007	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																											
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2007	Express Access/Savana Pro	Body	Radio																																																											
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																											
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2008	Express/Savana	Body	Body Control Module																																																											
G	2008	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2008	Express/Savana	Body	Passenger Presence System																																																											
G	2008	Express/Savana	Body	Radio																																																											
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2008	Express/Savana	Body	Rollover Sensor																																																											
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2008	Express/Savana	Body	Theft Deterrent Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2008	Express Access/Savana Pro	Body	Body Control Module																																																												
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2008	Express Access/Savana Pro	Body	Radio																																																											
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																											
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2009	Express/Savana	Body	Body Control Module																																																											
G	2009	Express/Savana	Body	Instrument Panel Cluster																																																											
G	2009	Express/Savana	Body	Passenger Presence System																																																											
G	2009	Express/Savana	Body	Radio																																																											
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
G	2009	Express/Savana	Body	Rollover Sensor																																																											
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
G	2009	Express/Savana	Body	Theft Deterrent Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
G	2009	Express Access/Savana Pro	Body	Body Control Module																																																											
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																											
G	2009	Express Access/Savana Pro	Body	Radio																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																													
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																													
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																													
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																											
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																													
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																													
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
G	2010	Express/Savana	Body	Body Control Module																																																													
G	2010	Express/Savana	Body	Instrument Panel Cluster																																																													
G	2010	Express/Savana	Body	Passenger Presence System																																																													
G	2010	Express/Savana	Body	Radio																																																													
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
G	2010	Express/Savana	Body	Rollover Sensor																																																													
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
G	2010	Express/Savana	Body	Theft Deterrent Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																											
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																																													
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
G	2010	Express Access/Savana Pro	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																															
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																															
G	2010	Express Access/Savana Pro	Body	Radio																																																															
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																																
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																																
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																																
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																																
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																																
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																																
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																																																
H	2004	Express/Savana	Chassis	VSES																																																																
H	2004	Express/Savana	Body	Body Control Module																																																																
H	2004	Express/Savana	Body	Instrument Panel Cluster																																																																
H	2004	Express/Savana	Body	Multifunction Alarm Module																																																																
H	2004	Express/Savana	Body	OnStar																																																																
H	2004	Express/Savana	Body	Base Radio																																																																
H	2004	Express/Savana	Body	Uplevel Radio																																																																
H	2004	Express/Savana	Body	Remote Function Actuation																																																																
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																																																
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																																
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																																
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																																
H	2004	Express Access/Savana Pro	Chassis	VSES																																																																
H	2004	Express Access/Savana Pro	Body	Body Control Module																																																																
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																																
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																																
H	2004	Express Access/Savana Pro	Body	OnStar																																																																
H	2004	Express Access/Savana Pro	Body	Base Radio																																																																
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																																																
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																																																
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																																
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																																
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																																
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																																
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																																
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																																																
H	2005	Express/Savana	Chassis	VSES																																																																
H	2005	Express/Savana	Body	Body Control Module																																																																
H	2005	Express/Savana	Body	Instrument Panel Cluster																																							V																							
H	2005	Express/Savana	Body	Multifunction Alarm Module																																																																
H	2005	Express/Savana	Body	Base Radio																																																																
H	2005	Express/Savana	Body	Uplevel Radio																																																																
H	2005	Express/Savana	Body	Remote Function Actuation																																																																
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																																																
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																																																
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																																
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																																
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																																
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																																
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																																
H	2005	Express Access/Savana Pro	Chassis	VSES																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2005	Express Access/Savana Pro	Body	Body Control Module																																																															
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								V																						
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																														
H	2005	Express Access/Savana Pro	Body	Base Radio																																																														
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																																														
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																																														
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																														
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																														
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																																															
H	2006	Express/Savana	Chassis	VSES																																																															
H	2006	Express/Savana	Body	Body Control Module																																																															
H	2006	Express/Savana	Body	Instrument Panel Cluster																																																															
H	2006	Express/Savana	Body	Multifunction Alarm Module																																																															
H	2006	Express/Savana	Body	Passenger Presence System																																																															
H	2006	Express/Savana	Body	Base Radio																																																															
H	2006	Express/Savana	Body	Uplevel Radio																																																															
H	2006	Express/Savana	Body	Remote Function Actuation																																																															
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																																															
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																																															
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																															
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																															
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																															
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																															
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																																															
H	2006	Express Access/Savana Pro	Chassis	VSES																																																															
H	2006	Express Access/Savana Pro	Body	Body Control Module																																																															
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																															
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																															
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																																															
H	2006	Express Access/Savana Pro	Body	Base Radio																																																															
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																																															
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																																															
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																															
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																															
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																															
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																															
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																															
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																															
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																															
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																															
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																															
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																															
H	2007	Express/Savana	Body	Body Control Module																																																															
H	2007	Express/Savana	Body	Instrument Panel Cluster																																																															
H	2007	Express/Savana	Body	Multifunction Alarm Module																																																															
H	2007	Express/Savana	Body	Passenger Presence System																																																															
H	2007	Express/Savana	Body	Base Radio																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2007	Express/Savana	Body	Uplevel Radio																																																												
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																																													
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																													
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																													
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																																													
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																																													
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																																													
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																																													
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																													
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																													
H	2007	Express Access/Savana Pro	Body	Body Control Module																																																													
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																													
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																																													
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																																													
H	2007	Express Access/Savana Pro	Body	Base Radio																																																													
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																																													
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																													
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																													
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																																													
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																													
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																													
H	2008	Express/Savana	Body	Body Control Module																																																													
H	2008	Express/Savana	Body	Instrument Panel Cluster																																																													
H	2008	Express/Savana	Body	Passenger Presence System																																																													
H	2008	Express/Savana	Body	Radio																																																													
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																																													
H	2008	Express/Savana	Body	Rollover Sensor																																																													
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																																													
H	2008	Express/Savana	Body	Theft Deterrent Module																																																													
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																													
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																													
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																													
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																													
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																													
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																													
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																													
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																													
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2008	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2008	Express Access/Savana Pro	Body	Radio																																																												
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2009	Express/Savana	Body	Body Control Module																																																												
H	2009	Express/Savana	Body	Instrument Panel Cluster																																																												
H	2009	Express/Savana	Body	Passenger Presence System																																																												
H	2009	Express/Savana	Body	Radio																																																											
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
H	2009	Express/Savana	Body	Rollover Sensor																																																												
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
H	2009	Express/Savana	Body	Theft Deterrent Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
H	2009	Express Access/Savana Pro	Body	Body Control Module																																																												
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																																												
H	2009	Express Access/Savana Pro	Body	Radio																																																												
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																																												
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2010	Express/Savana	Body	Body Control Module																																																											
H	2010	Express/Savana	Body	Instrument Panel Cluster																																																											
H	2010	Express/Savana	Body	Passenger Presence System																																																											
H	2010	Express/Savana	Body	Radio																																																											
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
H	2010	Express/Savana	Body	Rollover Sensor																																																											
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
H	2010	Express/Savana	Body	Theft Deterrent Module																																																											
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
H	2010	Express Access/Savana Pro	Body	Body Control Module																																																											
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																																											
H	2010	Express Access/Savana Pro	Body	Radio																																																											
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																																											
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																											
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																																									V		
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																											
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																																									V		
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																																									V		
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																									V		
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																											
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																											
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																									V		
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																											
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																											
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																									V		
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																									V		

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																														
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																															V
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																															V
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																															V
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																															
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																															V
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																																V
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																																V
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																																															
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																																															V
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																															
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																															V
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																															
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																															V
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																															V
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																																															
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																															
K	2004	ALL	Chassis	ABS Over 8600 GVW																																																															
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																																															
K	2004	ALL	Chassis	ESC																																																															
K	2004	ALL	Chassis	Rear Wheel Steering																																																															
K	2004	ALL	Chassis	Tire Pressure Monitor																																																															
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																																															
K	2004	ALL	Chassis	VSES																																																															
K	2004	ALL	Body	Amplifier (Bose)																																																															
K	2004	ALL	Body	Body Control Module																																																															
K	2004	ALL	Body	CD Changer																																																															
K	2004	ALL	Body	Chime																																																															
K	2004	ALL	Body	Driver Door Module																																																															
K	2004	ALL	Body	Driver Seat Module																																																															
K	2004	ALL	Body	Heating and Air Conditioning Auto																																																															
K	2004	ALL	Body	Heating and Air Conditioning Manual																																																															
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																																															
K	2004	ALL	Body	Instrument Panel Cluster																																																															
K	2004	ALL	Body	OnStar																																																															
K	2004	ALL	Body	Passenger Door Module																																																															
K	2004	ALL	Body	Passenger Presence System																																																															
K	2004	ALL	Body	Radio Base																																																															
K	2004	ALL	Body	Radio Uplevel																																																															
K	2004	ALL	Body	Radio Navigation																																																															
K	2004	ALL	Body	Rear Aux. Climate Module																																																															
K	2004	ALL	Body	Rear HVAC																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2004	ALL	Body	Rear Seat Audio																																																															
K	2004	ALL	Body	Rear Seat Entertainment																																																															
K	2004	ALL	Body	Supplemental Inflatable Restraint																																																															
K	2004	ALL	Body	Vehicle Theft Deterrent																																																															
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																															
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																															
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																															
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																															
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																															
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																																V
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																															
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																																
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																																
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																																
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																																V
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																																V
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																																V
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																															
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																															
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																																V
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																															
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																															
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																																																V
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																															
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																															
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																																																V
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																																																V
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																															
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																															
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																																																V
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																																																V
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																																																V
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																															
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																															
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																															
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																																																V
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																																																V
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																																																V
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																															
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																															
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																															
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																															
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																																															V
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																															
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																															
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																																															
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																																																V
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																																																V
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																												
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																												
K	2005	ALL	Chassis	ABS Over 8600 GVW																																																												
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																																												
K	2005	ALL	Chassis	ESC																																																												
K	2005	ALL	Chassis	Rear Wheel Steering																																																												
K	2005	ALL	Chassis	Tire Pressure Monitor																																																												
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																																												
K	2005	ALL	Chassis	VSES																																																												
K	2005	ALL	Body	Amplifier (Bose)																																																												
K	2005	ALL	Body	Body Control Module																																																												
K	2005	ALL	Body	CD Changer																																																												
K	2005	ALL	Body	Chime																																																												
K	2005	ALL	Body	Disc Player and Video Display																																																												
K	2005	ALL	Body	Driver Door Module																																																												
K	2005	ALL	Body	Driver Seat Module																																																												
K	2005	ALL	Body	Generator Battery Control Module																																																												
K	2005	ALL	Body	Heating and Air Conditioning Auto																																																												
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																																												
K	2005	ALL	Body	Heating and Air Conditioning Manual																																																												
K	2005	ALL	Body	Instrument Panel Cluster																																																												
K	2005	ALL	Body	Passenger Door Module																																																												
K	2005	ALL	Body	Passenger Presence System																																																												
K	2005	ALL	Body	Base Radio																																																												
K	2005	ALL	Body	Uplevel Radio																																																												
K	2005	ALL	Body	Navigation Radio																																																												
K	2005	ALL	Body	Rear Aux. Climate Module																																																												
K	2005	ALL	Body	Rear HVAC																																																												
K	2005	ALL	Body	Rear Seat Audio																																																												
K	2005	ALL	Body	Supplemental Inflatable Restraint																																																												
K	2005	ALL	Body	Vehicle Comm. Interface Module																																																												
K	2005	ALL	Body	Vehicle Theft Deterrent																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																																												
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																																												
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																																												
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																																												
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																																												
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																																												
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																																												
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																																												
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																									V															
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																									V															
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																									V															
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																																							
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																																							
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																									V															
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																									V															
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																									V															
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																																							
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																																							
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																																							
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																									V															
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																									V															
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																									V															
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																																							
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																																							
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																									V															
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																									V															
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																																							
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																																							
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																																							
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																									V															
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																																							
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																																							
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																																							
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																									V															
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																																							
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																																							
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																																							
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																									V															
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																									V															
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																																							
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																																							
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																																							
K	2006	ALL	Chassis	ABS Over 8600 GVW																																																							
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																																							
K	2006	ALL	Chassis	ESC																																																							
K	2006	ALL	Chassis	Tire Pressure Monitor																																																							
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																																							
K	2006	ALL	Chassis	VSES																																																							
K	2006	ALL	Body	Amplifier (Bose)																																																							
K	2006	ALL	Body	Body Control Module																																																							
K	2006	ALL	Body	CD Changer																																																							
K	2006	ALL	Body	Chime																																																							
K	2006	ALL	Body	Disc Player and Video Display																																																							
K	2006	ALL	Body	Driver Door Module																																																							
K	2006	ALL	Body	Driver Seat Module																																																							
K	2006	ALL	Body	Generator Battery Control Module																																																							
K	2006	ALL	Body	Heating and Air Conditioning Auto																																																							

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																																										
K	2006	ALL	Body	Heating and Air Conditioning Manual																																																											
K	2006	ALL	Body	Instrument Panel Cluster																																																											
K	2006	ALL	Body	Passenger Door Module																																																											
K	2006	ALL	Body	Passenger Presence System																																																											
K	2006	ALL	Body	Base Radio																																																											
K	2006	ALL	Body	Uplevel Radio																																																											
K	2006	ALL	Body	Navigation Radio																																																											
K	2006	ALL	Body	Rear Aux. Climate Module																																																											
K	2006	ALL	Body	Rear HVAC																																																											
K	2006	ALL	Body	Rear Seat Audio																																																											
K	2006	ALL	Body	Supplemental Inflatable Restraint																																																											
K	2006	ALL	Body	Vehicle Theft Deterrent																																																											
K	2006	ALL	Body	Vehicle Comm. Interface Module																																																											
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																											
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																													
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																														
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																														
K	2007	Sierra	Chassis	Electronic Suspension Control																																																														
K	2007	Sierra	Chassis	Trailer Brake Control Module																																																														
K	2007	Sierra	Body	Amplifier (Bose)																																																														
K	2007	Sierra	Body	Body Control Module																																																														
K	2007	Sierra	Body	Body Control Module (aux.)																																																														
K	2007	Sierra	Body	Digital Radio Receiver																																																														
K	2007	Sierra	Body	Driver Door Switch																																																														
K	2007	Sierra	Body	HVAC Control Module Auto																																																														
K	2007	Sierra	Body	HVAC Control Module Manual																																																														
K	2007	Sierra	Body	Instrument Panel Cluster																																																														
K	2007	Sierra	Body	Memory Seat Module																																																														
K	2007	Sierra	Body	Park Assist Module																																																														
K	2007	Sierra	Body	Passenger Door Switch																																																														
K	2007	Sierra	Body	Passenger Presence System																																																														
K	2007	Sierra	Body	Radio																																																														
K	2007	Sierra	Body	Rear Heated Seat Module																																																														
K	2007	Sierra	Body	Rear HVAC/RSA																																																														
K	2007	Sierra	Body	Rollover Sensor																																																														
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																																														
K	2007	Sierra	Body	Theft Deterrent Module																																																														
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																														
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																														
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																														
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																														
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																														
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																														
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																														
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																																														
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																																														
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																																														
K	2007	Yukon	Chassis	Electronic Suspension Control																																																														
K	2007	Yukon	Chassis	Trailer Brake Control Module																																																														
K	2007	Yukon	Body	Amplifier (Bose)																																																														
K	2007	Yukon	Body	Assist Step Controller																																																														
K	2007	Yukon	Body	Body Control Module																																																														
K	2007	Yukon	Body	Body Control Module (aux.)																																																														
K	2007	Yukon	Body	Digital Radio Receiver																																																														
K	2007	Yukon	Body	Driver Door Switch																																																														
K	2007	Yukon	Body	HVAC Control Module Auto																																																														
K	2007	Yukon	Body	HVAC Control Module Manual																																																														
K	2007	Yukon	Body	Instrument Panel Cluster																																																														
K	2007	Yukon	Body	Lift Gate Module																																																														
K	2007	Yukon	Body	Memory Seat Module																																																														
K	2007	Yukon	Body	Park Assist Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2007	Yukon	Body	Passenger Door Switch																																																											
K	2007	Yukon	Body	Passenger Presence System																																																												
K	2007	Yukon	Body	Radio																																																												
K	2007	Yukon	Body	Rear Heated Seat Module																																																												
K	2007	Yukon	Body	Rear HVAC/RSA																																																												
K	2007	Yukon	Body	Rollover Sensor																																																												
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																																												
K	2007	Yukon	Body	Theft Deterrent Module																																																												
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																												
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																												
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																												
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																												
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																																												
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																																												
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																																												
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																																												
K	2007	Yukon XL	Body	Amplifier (Bose)																																																												
K	2007	Yukon XL	Body	Assist Step Controller																																																												
K	2007	Yukon XL	Body	Body Control Module																																																												
K	2007	Yukon XL	Body	Body Control Module (aux.)																																																												
K	2007	Yukon XL	Body	Digital Radio Receiver																																																												
K	2007	Yukon XL	Body	Driver Door Switch																																																												
K	2007	Yukon XL	Body	HVAC Control Module Auto																																																												
K	2007	Yukon XL	Body	HVAC Control Module Manual																																																												
K	2007	Yukon XL	Body	Instrument Panel Cluster																																																												
K	2007	Yukon XL	Body	Lift Gate Module																																																												
K	2007	Yukon XL	Body	Memory Seat Module																																																												
K	2007	Yukon XL	Body	Park Assist Module																																																												
K	2007	Yukon XL	Body	Passenger Door Switch																																																												
K	2007	Yukon XL	Body	Passenger Presence System																																																												
K	2007	Yukon XL	Body	Radio																																																												
K	2007	Yukon XL	Body	Rear Heated Seat Module																																																												
K	2007	Yukon XL	Body	Rear HVAC/RSA																																																												
K	2007	Yukon XL	Body	Rollover Sensor																																																												
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
K	2007	Yukon XL	Body	Theft Deterrent Module																																																												
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																										
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																										
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																										
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																										
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																																										
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																																										
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																																										
K	2008	Sierra	Chassis	Electronic Suspension Control																																																										
K	2008	Sierra	Chassis	Trailer Brake Control Module																																																										
K	2008	Sierra	Body	Amplifier (Bose)																																																										
K	2008	Sierra	Body	Body Control Module																																																										
K	2008	Sierra	Body	Body Control Module (aux.)																																																										
K	2008	Sierra	Body	Digital Radio Receiver																																																										
K	2008	Sierra	Body	Driver Door Switch																																																										
K	2008	Sierra	Body	HVAC Control Module Auto																																																										
K	2008	Sierra	Body	HVAC Control Module Manual																																																										
K	2008	Sierra	Body	Instrument Panel Cluster																																																										
K	2008	Sierra	Body	Memory Seat Module																																																										
K	2008	Sierra	Body	Park Assist Module																																																										
K	2008	Sierra	Body	Passenger Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2008	Sierra	Body	Passenger Presence System																																																											
K	2008	Sierra	Body	Radio																																																											
K	2008	Sierra	Body	Rear Heated Seat Module																																																											
K	2008	Sierra	Body	Rear HVAC/RSA																																																											
K	2008	Sierra	Body	Rollover Sensor																																																											
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																																											
K	2008	Sierra	Body	Remote Control Door Lock Receiver																																																											
K	2008	Sierra	Body	Theft Deterrent Module																																																											
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																											
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																											
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																											
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Yukon	Chassis	Electronic Brake Control Module																																																											
K	2008	Yukon	Chassis	Electronic Suspension Control																																																											
K	2008	Yukon	Chassis	Trailer Brake Control Module																																																											
K	2008	Yukon	Body	Amplifier (Bose)																																																											
K	2008	Yukon	Body	Assist Step Controller																																																											
K	2008	Yukon	Body	Body Control Module																																																											
K	2008	Yukon	Body	Body Control Module (aux.)																																																											
K	2008	Yukon	Body	Digital Radio Receiver																																																											
K	2008	Yukon	Body	Driver Door Switch																																																											
K	2008	Yukon	Body	HVAC Control Module Auto																																																											
K	2008	Yukon	Body	HVAC Control Module Manual																																																											
K	2008	Yukon	Body	Instrument Panel Cluster																																																											
K	2008	Yukon	Body	Lift Gate Module																																																											
K	2008	Yukon	Body	Memory Seat Module																																																											
K	2008	Yukon	Body	Park Assist Module																																																											
K	2008	Yukon	Body	Passenger Door Switch																																																											
K	2008	Yukon	Body	Passenger Presence System																																																											
K	2008	Yukon	Body	Radio																																																											
K	2008	Yukon	Body	Rear Heated Seat Module																																																											
K	2008	Yukon	Body	Rear HVAC/RSA																																																											
K	2008	Yukon	Body	Rollover Sensor																																																											
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																																											
K	2008	Yukon	Body	Theft Deterrent Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																									
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																										
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module				V																																																							
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																											
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																																											
K	2008	Yukon Hybrid	Body	Body Control Module																																																											
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																																											
K	2008	Yukon Hybrid	Body	Driver Door Switch																																																											
K	2008	Yukon Hybrid	Body	HVAC Control Module																																																											
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
K	2008	Yukon Hybrid	Body	Lift Gate Module																																																											
K	2008	Yukon Hybrid	Body	Memory Seat Module																																																											
K	2008	Yukon Hybrid	Body	Park Assist Module																																																											
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																																											
K	2008	Yukon Hybrid	Body	Passenger Presence System																																																											
K	2008	Yukon Hybrid	Body	Radio																																																											
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																																											
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																																											
K	2008	Yukon Hybrid	Body	Rollover Sensor																																																											
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																																											
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																											
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																																											
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																																											
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																																												
K	2008	Yukon XL	Body	Amplifier (Bose)																																																												
K	2008	Yukon XL	Body	Assist Step Controller																																																												
K	2008	Yukon XL	Body	Body Control Module																																																												
K	2008	Yukon XL	Body	Body Control Module (aux.)																																																												
K	2008	Yukon XL	Body	Digital Radio Receiver																																																												
K	2008	Yukon XL	Body	Driver Door Switch																																																												
K	2008	Yukon XL	Body	HVAC Control Module Auto																																																												
K	2008	Yukon XL	Body	HVAC Control Module Manual																																																												
K	2008	Yukon XL	Body	Instrument Panel Cluster																																																												
K	2008	Yukon XL	Body	Lift Gate Module																																																												
K	2008	Yukon XL	Body	Memory Seat Module																																																												
K	2008	Yukon XL	Body	Park Assist Module																																																												
K	2008	Yukon XL	Body	Passenger Door Switch																																																												
K	2008	Yukon XL	Body	Passenger Presence System																																																												
K	2008	Yukon XL	Body	Radio																																																												
K	2008	Yukon XL	Body	Rear Heated Seat Module																																																												
K	2008	Yukon XL	Body	Rear HVAC/RSA																																																												
K	2008	Yukon XL	Body	Rollover Sensor																																																												
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
K	2008	Yukon XL	Body	Theft Deterrent Module																																																												
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																												
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto					V																																																							
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul					V																																																							
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																												
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																												
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																												
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
K	2009	Sierra	Chassis	Electronic Suspension Control																																																												
K	2009	Sierra	Chassis	Trailer Brake Control Module																																																												
K	2009	Sierra	Body	Amplifier (Bose)																																																												
K	2009	Sierra	Body	Body Control Module																																																											
K	2009	Sierra	Body	Body Control Module (aux.)																																																											
K	2009	Sierra	Body	Digital Radio Receiver																																																											
K	2009	Sierra	Body	Driver Door Switch																																																											
K	2009	Sierra	Body	HVAC Control Module Auto																																																											
K	2009	Sierra	Body	HVAC Control Module Manual																																																											
K	2009	Sierra	Body	Instrument Panel Cluster																																																											
K	2009	Sierra	Body	Memory Seat Module																																																											
K	2009	Sierra	Body	Park Assist Module																																																											
K	2009	Sierra	Body	Passenger Door Switch																																																											
K	2009	Sierra	Body	Passenger Presence System																																																											
K	2009	Sierra	Body	Radio																																																											
K	2009	Sierra	Body	Rear Heated Seat Module																																																											
K	2009	Sierra	Body	Rear HVAC/RSA																																																											
K	2009	Sierra	Body	Rollover Sensor																																																											
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																																											
K	2009	Sierra	Body	Theft Deterrent Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																									
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																											
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																											
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																											
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																																											
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module				V																																																						
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																																											
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																																											
K	2009	Sierra Hybrid	Body	Body Control Module																																																												
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Sierra Hybrid	Body	Driver Door Switch																																																												
K	2009	Sierra Hybrid	Body	HVAC Control Module																																																												
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
K	2009	Sierra Hybrid	Body	Memory Seat Module																																																												
K	2009	Sierra Hybrid	Body	Park Assist Module																																																												
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																																												
K	2009	Sierra Hybrid	Body	Passenger Presence System																																																												
K	2009	Sierra Hybrid	Body	Radio																																																												
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Sierra Hybrid	Body	Rollover Sensor																																																												
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Sierra Hybrid	Body	Theft Deterrent Module																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																																												
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																																												
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																												
K	2009	Yukon	Chassis	Electronic Brake Control Module																																																												
K	2009	Yukon	Chassis	Electronic Suspension Control																																																												
K	2009	Yukon	Chassis	Trailer Brake Control Module																																																												
K	2009	Yukon	Body	Amplifier (Bose)																																																												
K	2009	Yukon	Body	Assist Step Controller																																																												
K	2009	Yukon	Body	Body Control Module																																																												
K	2009	Yukon	Body	Body Control Module (aux.)																																																												
K	2009	Yukon	Body	Digital Radio Receiver																																																												
K	2009	Yukon	Body	Driver Door Switch																																																												
K	2009	Yukon	Body	HVAC Control Module Auto																																																												
K	2009	Yukon	Body	HVAC Control Module Manual																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2009	Yukon	Body	Instrument Panel Cluster																																																												
K	2009	Yukon	Body	Left Side Object Detection Module																																																												
K	2009	Yukon	Body	Lift Gate Module																																																												
K	2009	Yukon	Body	Memory Seat Module																																																												
K	2009	Yukon	Body	Park Assist Module																																																												
K	2009	Yukon	Body	Passenger Door Switch																																																												
K	2009	Yukon	Body	Passenger Presence System																																																												
K	2009	Yukon	Body	Radio																																																												
K	2009	Yukon	Body	Rear Heated Seat Module																																																												
K	2009	Yukon	Body	Rear HVAC/RSA																																																												
K	2009	Yukon	Body	Right Side Object Detection Module																																																												
K	2009	Yukon	Body	Rollover Sensor																																																												
K	2009	Yukon	Body	Supplemental Inflatable Restraint																																																												
K	2009	Yukon	Body	Theft Deterrent Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module	V	V																																																										
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																																												
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																																												
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module				V																																																								
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																																												
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																																												
K	2009	Yukon Hybrid	Body	Body Control Module																																																												
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																																												
K	2009	Yukon Hybrid	Body	Driver Door Switch																																																												
K	2009	Yukon Hybrid	Body	Heated Seat Module																																																												
K	2009	Yukon Hybrid	Body	HVAC Control Module																																																												
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
K	2009	Yukon Hybrid	Body	Park Assist Module																																																												
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																																												
K	2009	Yukon Hybrid	Body	Passenger Presence System																																																												
K	2009	Yukon Hybrid	Body	Radio																																																												
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
K	2009	Yukon Hybrid	Body	Rollover Sensor																																																												
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2009	Yukon Hybrid	Body	Theft Deterrent Module																																																												
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																																												
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																																												
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																																												
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module					V																																																								
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																														
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																														
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																																														
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																																														
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																																														
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																																														
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																														
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																														
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																																															
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																															
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																																															
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																																															
K	2009	Yukon XL	Body	Amplifier (Bose)																																																															
K	2009	Yukon XL	Body	Assist Step Controller																																																															
K	2009	Yukon XL	Body	Body Control Module																																																															
K	2009	Yukon XL	Body	Body Control Module (aux.)																																																															
K	2009	Yukon XL	Body	Digital Radio Receiver																																																															
K	2009	Yukon XL	Body	Driver Door Switch																																																															
K	2009	Yukon XL	Body	HVAC Control Module Auto																																																															
K	2009	Yukon XL	Body	HVAC Control Module Manual																																																															
K	2009	Yukon XL	Body	Instrument Panel Cluster																																																															
K	2009	Yukon XL	Body	Left Side Object Detection Module																																																															
K	2009	Yukon XL	Body	Lift Gate Module																																																															
K	2009	Yukon XL	Body	Memory Seat Module																																																															
K	2009	Yukon XL	Body	Park Assist Module																																																															
K	2009	Yukon XL	Body	Passenger Door Switch																																																															
K	2009	Yukon XL	Body	Passenger Presence System																																																															
K	2009	Yukon XL	Body	Radio																																																															
K	2009	Yukon XL	Body	Rear Heated Seat Module																																																															
K	2009	Yukon XL	Body	Rear HVAC/RSA																																																															
K	2009	Yukon XL	Body	Right Side Object Detection Module																																																															
K	2009	Yukon XL	Body	Rollover Sensor																																																															
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																																															
K	2009	Yukon XL	Body	Theft Deterrent Module																																																															
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																															
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																																															
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																																										
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																																											
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																											
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																											
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																																											
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																																											
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																																											
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																																											
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																																											
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																											
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																											
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																											
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																											
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																											
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																											
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																											
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																											
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																											
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																											
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																											
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																											
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																											
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																											
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																											
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																											
K	2010	Sierra	Chassis	Electronic Suspension Control																																																											
K	2010	Sierra	Chassis	Trailer Brake Control Module																																																											
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																																											
K	2010	Sierra	Body	Amplifier (Bose)																																																											
K	2010	Sierra	Body	Body Control Module																																																										
K	2010	Sierra	Body	Body Control Module (aux.)																																																											
K	2010	Sierra	Body	Digital Radio Receiver																																																											
K	2010	Sierra	Body	Driver Door Switch																																																											
K	2010	Sierra	Body	HVAC Control Module Auto																																																											
K	2010	Sierra	Body	HVAC Control Module Manual																																																											
K	2010	Sierra	Body	Instrument Panel Cluster																																																											
K	2010	Sierra	Body	Memory Seat Module																																																											
K	2010	Sierra	Body	Park Assist Module																																																											
K	2010	Sierra	Body	Passenger Door Switch																																																											
K	2010	Sierra	Body	Passenger Presence System																																																											
K	2010	Sierra	Body	Radio																																																											
K	2010	Sierra	Body	Rear Heated Seat Module																																																											
K	2010	Sierra	Body	Rear HVAC/RSA																																																											
K	2010	Sierra	Body	Supplemental Inflatable Restraint																																																											
K	2010	Sierra	Body	Theft Deterrent Module																																																											
K	2010	Sierra Hybrid	Powertrain	Engine Control Module																																																											
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																											
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																										
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																												
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module				V																																																								
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Sierra Hybrid	Body	Body Control Module																																																												
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																																												
K	2010	Sierra Hybrid	Body	Driver Door Switch																																																												
K	2010	Sierra Hybrid	Body	Heated Seat Module																																																												
K	2010	Sierra Hybrid	Body	HVAC Control Module																																																												
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
K	2010	Sierra Hybrid	Body	Park Assist Module																																																												
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																																												
K	2010	Sierra Hybrid	Body	Passenger Presence System																																																												
K	2010	Sierra Hybrid	Body	Radio																																																												
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																																																												
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																												
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																												
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																												
K	2010	Yukon	Chassis	Electronic Brake Control Module																																																												
K	2010	Yukon	Chassis	Electronic Suspension Control																																																												
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon	Body	Amplifier (Bose)																																																												
K	2010	Yukon	Body	Assist Step Controller																																																												
K	2010	Yukon	Body	Body Control Module																																																												
K	2010	Yukon	Body	Body Control Module (aux.)																																																												
K	2010	Yukon	Body	Digital Radio Receiver																																																												
K	2010	Yukon	Body	Driver Door Switch																																																												
K	2010	Yukon	Body	HVAC Control Module Auto																																																												
K	2010	Yukon	Body	HVAC Control Module Manual																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2010	Yukon	Body	Instrument Panel Cluster																																																											
K	2010	Yukon	Body	Left Side Object Detection Module																																																												
K	2010	Yukon	Body	Lift Gate Module																																																												
K	2010	Yukon	Body	Memory Seat Module																																																												
K	2010	Yukon	Body	Park Assist Module																																																												
K	2010	Yukon	Body	Passenger Door Switch																																																												
K	2010	Yukon	Body	Passenger Presence System																																																												
K	2010	Yukon	Body	Radio																																																												
K	2010	Yukon	Body	Rear Heated Seat Module																																																												
K	2010	Yukon	Body	Rear HVAC/RSA																																																												
K	2010	Yukon	Body	Right Side Object Detection Module																																																												
K	2010	Yukon	Body	Supplemental Inflatable Restraint																																																												
K	2010	Yukon	Body	Theft Deterrent Module																																																												
K	2010	Yukon Hybrid	Powertrain	Engine Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																																												
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																										
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																												
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																												
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																																												
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																												
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																																												
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module				V																																																							
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																																												
K	2010	Yukon Hybrid	Body	Body Control Module																																																												
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																																												
K	2010	Yukon Hybrid	Body	Driver Door Switch																																																												
K	2010	Yukon Hybrid	Body	Heated Seat Module																																																												
K	2010	Yukon Hybrid	Body	HVAC Control Module																																																												
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
K	2010	Yukon Hybrid	Body	Lift Gate Module																																																												
K	2010	Yukon Hybrid	Body	Park Assist Module																																																												
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																																												
K	2010	Yukon Hybrid	Body	Passenger Presence System																																																												
K	2010	Yukon Hybrid	Body	Radio																																																												
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																																																												
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																													
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																													
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																																													
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																													
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																													
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																													
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																																													
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																																													
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																																													
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																																													
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																																													
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																																													
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																																														
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																																														
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																																														
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																														
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																														
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																																														
K	2010	Yukon XL	Body	Amplifier (Bose)																																																														
K	2010	Yukon XL	Body	Assist Step Controller																																																														
K	2010	Yukon XL	Body	Body Control Module																																																														
K	2010	Yukon XL	Body	Body Control Module (aux.)																																																														
K	2010	Yukon XL	Body	Digital Radio Receiver																																																														
K	2010	Yukon XL	Body	Driver Door Switch																																																														
K	2010	Yukon XL	Body	HVAC Control Module Auto																																																														
K	2010	Yukon XL	Body	HVAC Control Module Manual																																																														
K	2010	Yukon XL	Body	Instrument Panel Cluster																																																														
K	2010	Yukon XL	Body	Left Side Object Detection Module																																																														
K	2010	Yukon XL	Body	Lift Gate Module																																																														
K	2010	Yukon XL	Body	Memory Seat Module																																																														
K	2010	Yukon XL	Body	Park Assist Module																																																														
K	2010	Yukon XL	Body	Passenger Door Switch																																																														
K	2010	Yukon XL	Body	Passenger Presence System																																																														
K	2010	Yukon XL	Body	Radio																																																														
K	2010	Yukon XL	Body	Rear Heated Seat Module																																																														
K	2010	Yukon XL	Body	Rear HVAC/RSA																																																														
K	2010	Yukon XL	Body	Right Side Object Detection Module																																																														
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																																														
K	2010	Yukon XL	Body	Theft Deterrent Module																																																														
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																														
L	2004	ALL	Chassis	4WAL 3 Sensor																																																														
L	2004	ALL	Body	Body Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2004	ALL	Body	Instrument Panel Cluster																																																														
L	2004	ALL	Body	Supplemental Inflatable Restraint																																																														
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																														
L	2005	ALL	Chassis	4WAL 3 Sensor																																																														
L	2005	ALL	Body	Body Control Module																																																					V	V	V	V							
L	2005	ALL	Body	Instrument Panel Cluster																																																														
L	2005	ALL	Body	Supplemental Inflatable Restraint																																																														
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																																														
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																																														
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																																														
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																																														
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																																														
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																																														
L	2010	Terrain	Chassis	Electronic Brake Control Module																																																														
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2010	Terrain	Body	Body Control Module																																																														
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2010	Terrain	Body	Passenger Presence Module																																																														
L	2010	Terrain	Body	Instrument Cluster																																																														
L	2010	Terrain	Body	Radio																																																														
L	2010	Terrain	Body	Multimedia Player Interface Module																																																														
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																																														
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																														
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																														
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																																														
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																																														
L	2010	Terrain	Body	Liftgate Control Module																																																														
L	2010	Terrain	Body	Parking Assist Control Module																																																														
L	2010	Terrain	Body	Frontview Camera Module																																																														
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																																														
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																																														
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																																														
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																														
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																														
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																																														
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																																														
L	2011	Terrain	Chassis	Electronic Brake Control Module																																																														
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																														
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																														
L	2011	Terrain	Body	Body Control Module																																																														
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
L	2011	Terrain	Body	Passenger Presence Module																																																														
L	2011	Terrain	Body	Instrument Cluster																																																														
L	2011	Terrain	Body	Radio																																																														
L	2011	Terrain	Body	Multimedia Player Interface Module																																																														
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																														
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																														
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																																											
L	2011	Terrain	Body	Liftgate Control Module																																																												
L	2011	Terrain	Body	Parking Assist Control Module																																																												
L	2011	Terrain	Body	Frontview Camera Module																																																												
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																																												
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																																												
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																																												
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2012	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2012	Terrain	Body	Body Control Module																																																												
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2012	Terrain	Body	Passenger Presence Module																																																												
L	2012	Terrain	Body	Instrument Cluster																																																												
L	2012	Terrain	Body	Radio																																																												
L	2012	Terrain	Body	Multimedia Player Interface Module																																																												
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2012	Terrain	Body	Liftgate Control Module																																																												
L	2012	Terrain	Body	Parking Assist Control Module																																																												
L	2012	Terrain	Body	Frontview Camera Module																																																												
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																																												
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2013	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2013	Terrain	Chassis	Power Steering Control Module																																																												
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																																												
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2013	Terrain	Body	Passenger Presence Module																																																												
L	2013	Terrain	Body	Instrument Cluster																																																												
L	2013	Terrain	Body	Radio																																																												
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2013	Terrain	Body	Liftgate Control Module																																																												
L	2013	Terrain	Body	Right Side Object Detection Control Module																																																												
L	2013	Terrain	Body	Left Side Object Detection Control Module																																																												
L	2013	Terrain	Body	Parking Assist Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2013	Terrain	Body	Frontview Camera Module																																																											
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2014	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2014	Terrain	Chassis	Power Steering Control Module																																																												
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																																												
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2014	Terrain	Body	Passenger Presence Module																																																												
L	2014	Terrain	Body	Instrument Cluster																																																												
L	2014	Terrain	Body	Radio																																																												
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																																												
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																												
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2014	Terrain	Body	Liftgate Control Module																																																												
L	2014	Terrain	Body	Right Side Object Detection Control Module																																																												
L	2014	Terrain	Body	Left Side Object Detection Control Module																																																												
L	2014	Terrain	Body	Parking Assist Control Module																																																												
L	2014	Terrain	Body	Frontview Camera Module																																																												
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																																												
L	2015	Terrain	Chassis	Electronic Brake Control Module																																																												
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																												
L	2015	Terrain	Chassis	Power Steering Control Module																																																												
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																												
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																																												
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																												
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
L	2015	Terrain	Body	Passenger Presence Module																																																												
L	2015	Terrain	Body	Instrument Cluster																																																												
L	2015	Terrain	Body	Radio																																																												
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																																												
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																																												
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																																												
L	2015	Terrain	Body	Liftgate Control Module																																																												
L	2015	Terrain	Body	Seat Memory Control Module																																																												
L	2015	Terrain	Body	Right Side Object Detection Control Module																																																												
L	2015	Terrain	Body	Left Side Object Detection Control Module																																																												
L	2015	Terrain	Body	Parking Assist Control Module																																																												
L	2015	Terrain	Body	Frontview Camera Module																																																												
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																																												
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																																													
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																																													
L	2016	Terrain	Chassis	Electronic Brake Control Module																																																													
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																																													
L	2016	Terrain	Chassis	Power Steering Control Module																																																													
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																																													
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																																													
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																																													
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
L	2016	Terrain	Body	Passenger Presence Module																																																													
L	2016	Terrain	Body	Instrument Cluster																																																													
L	2016	Terrain	Body	Radio																																																													
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																																													
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																																													
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																																													
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																																													
L	2016	Terrain	Body	Liftgate Control Module																																																													
L	2016	Terrain	Body	Seat Memory Control Module																																																													
L	2016	Terrain	Body	Right Side Object Detection Control Module																																																													
L	2016	Terrain	Body	Left Side Object Detection Control Module																																																													
L	2016	Terrain	Body	Parking Assist Control Module																																																													
L	2016	Terrain	Body	Frontview Camera Module																																																													
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
M	2004	ALL	Chassis	4WAL 3 Sensor																																																													
M	2004	ALL	Body	Body Control Module																																													V	V	V	V												
M	2004	ALL	Body	Instrument Panel Cluster																																																													
M	2004	ALL	Body	Supplemental Inflatable Restraint																																																													
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
M	2005	ALL	Chassis	4WAL 3 Sensor																																																													
M	2005	ALL	Body	Body Control Module																																													V	V	V	V												
M	2005	ALL	Body	Instrument Panel Cluster																																																													
M	2005	ALL	Body	Supplemental Inflatable Restraint																																																													
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																													
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																													
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																																													
P	2007	ALL	Body	Supplemental Inflatable Restraint																																																													
P	2007	ALL	Body	Theft Deterrent Module																																																													
R	2007	ALL	Powertrain	Engine Control Module																																																													
R	2007	ALL	Powertrain	Transmission Control Module																																																													
R	2007	ALL	Chassis	Electronic Brake Control Module																																																													
R	2007	ALL	Body	Body Control Module																																																													
R	2007	ALL	Body	Digital Radio Receiver																																																													
R	2007	ALL	Body	Driver Door Switch																																																													
R	2007	ALL	Body	Head Up Display																																																													
R	2007	ALL	Body	Heated Seat Module																																																													
R	2007	ALL	Body	HVAC Control Module Auto																																																													
R	2007	ALL	Body	HVAC Control Module Manual																																																													
R	2007	ALL	Body	Instrument Panel Cluster																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
R	2007	ALL	Body	Lift Gate Module																																																												
R	2007	ALL	Body	Park Assist Module																																																												
R	2007	ALL	Body	Passenger Door Switch																																																												
R	2007	ALL	Body	Passenger Presence System																																																												
R	2007	ALL	Body	Radio																																																												
R	2007	ALL	Body	Rear HVAC/RSA																																																												
R	2007	ALL	Body	Rollover Sensor																																																												
R	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2007	ALL	Body	Theft Deterrent Module																																																												
R	2008	ALL	Powertrain	Engine Control Module																																																												
R	2008	ALL	Powertrain	Transmission Control Module																																																												
R	2008	ALL	Chassis	Electronic Brake Control Module																																																												
R	2008	ALL	Body	Body Control Module																																																												
R	2008	ALL	Body	Digital Radio Receiver																																																												
R	2008	ALL	Body	Driver Door Switch																																																												
R	2008	ALL	Body	Head Up Display																																																												
R	2008	ALL	Body	Heated Seat Module																																																												
R	2008	ALL	Body	HVAC Control Module Auto																																																												
R	2008	ALL	Body	HVAC Control Module Manual																																																												
R	2008	ALL	Body	Instrument Panel Cluster																																																												
R	2008	ALL	Body	Lift Gate Module																																																												
R	2008	ALL	Body	Park Assist Module																																																												
R	2008	ALL	Body	Passenger Door Switch																																																												
R	2008	ALL	Body	Passenger Presence System																																																												
R	2008	ALL	Body	Radio																																																												
R	2008	ALL	Body	Rear HVAC/RSA																																																												
R	2008	ALL	Body	Rollover Sensor																																																												
R	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2008	ALL	Body	Theft Deterrent Module																																																												
R	2009	ALL	Powertrain	Engine Control Module																																																												
R	2009	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2009	ALL	Powertrain	Transmission Control Module																																																												
R	2009	ALL	Chassis	Electronic Brake Control Module																																																												
R	2009	ALL	Body	Body Control Module																																																												
R	2009	ALL	Body	Digital Radio Receiver																																																												
R	2009	ALL	Body	Driver Door Switch																																																												
R	2009	ALL	Body	Head Up Display																																																												
R	2009	ALL	Body	Heated Seat Module																																																												
R	2009	ALL	Body	HVAC Control Module Auto																																																												
R	2009	ALL	Body	HVAC Control Module Manual																																																												
R	2009	ALL	Body	Instrument Panel Cluster																																																												
R	2009	ALL	Body	Lift Gate Module																																																												
R	2009	ALL	Body	Park Assist Module																																																												
R	2009	ALL	Body	Passenger Door Switch																																																												
R	2009	ALL	Body	Passenger Presence System																																																												
R	2009	ALL	Body	Radio																																																												
R	2009	ALL	Body	Rear HVAC/RSA																																																												
R	2009	ALL	Body	Rollover Sensor																																																												
R	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2009	ALL	Body	Theft Deterrent Module																																																												
R	2010	ALL	Powertrain	Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
R	2010	ALL	Powertrain	Fuel Pump Control Module																																																														
R	2010	ALL	Powertrain	Transmission Control Module																																																															
R	2010	ALL	Chassis	Electronic Brake Control Module																																																															
R	2010	ALL	Body	Body Control Module																																																															
R	2010	ALL	Body	Digital Radio Receiver																																																															
R	2010	ALL	Body	Driver Door Switch																																																															
R	2010	ALL	Body	Head Up Display																																																															
R	2010	ALL	Body	Heated Seat Module																																																															
R	2010	ALL	Body	HVAC Control Module Auto																																																															
R	2010	ALL	Body	HVAC Control Module Manual																																																															
R	2010	ALL	Body	Instrument Panel Cluster																																																															
R	2010	ALL	Body	Lift Gate Module																																																															
R	2010	ALL	Body	Park Assist Module																																																															
R	2010	ALL	Body	Passenger Door Switch																																																															
R	2010	ALL	Body	Passenger Presence System																																																															
R	2010	ALL	Body	Radio																																																															
R	2010	ALL	Body	Rear HVAC/RSA																																																															
R	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
R	2010	ALL	Body	Theft Deterrent Module																																																															
R	2011	ALL	Powertrain	Engine Control Module																																																															
R	2011	ALL	Powertrain	Fuel Pump Control Module																																																															
R	2011	ALL	Powertrain	Transmission Control Module																																																															
R	2011	ALL	Chassis	Electronic Brake Control Module																																																															
R	2011	ALL	Body	Body Control Module																																																															
R	2011	ALL	Body	Digital Radio Receiver																																																															
R	2011	ALL	Body	Driver Door Switch																																																															
R	2011	ALL	Body	Head Up Display																																																															
R	2011	ALL	Body	Heated Seat Module																																																															
R	2011	ALL	Body	HVAC Control Module Auto																																																															
R	2011	ALL	Body	HVAC Control Module Manual																																																															
R	2011	ALL	Body	Instrument Panel Cluster																																																															
R	2011	ALL	Body	Lift Gate Module																																																															
R	2011	ALL	Body	Park Assist Module																																																															
R	2011	ALL	Body	Passenger Door Switch																																																															
R	2011	ALL	Body	Passenger Presence System																																																															
R	2011	ALL	Body	Radio																																																															
R	2011	ALL	Body	Rear HVAC/RSA																																																															
R	2011	ALL	Body	Supplemental Inflatable Restraint																																																															
R	2011	ALL	Body	Theft Deterrent Module																																																															
R	2012	ALL	Powertrain	Engine Control Module																																																															
R	2012	ALL	Powertrain	Fuel Pump Control Module																																																															
R	2012	ALL	Powertrain	Transmission Control Module																																																															
R	2012	ALL	Chassis	Electronic Brake Control Module																																																															
R	2012	ALL	Body	Body Control Module																																																															
R	2012	ALL	Body	Digital Radio Receiver																																																															
R	2012	ALL	Body	Driver Door Switch																																																															
R	2012	ALL	Body	Head Up Display																																																															
R	2012	ALL	Body	Heated Seat Module																																																															
R	2012	ALL	Body	HVAC Control Module Auto																																																															
R	2012	ALL	Body	HVAC Control Module Manual																																																															
R	2012	ALL	Body	Instrument Panel Cluster																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
R	2012	ALL	Body	Lift Gate Module																																																												
R	2012	ALL	Body	Park Assist Module																																																												
R	2012	ALL	Body	Passenger Door Switch																																																												
R	2012	ALL	Body	Passenger Presence System																																																												
R	2012	ALL	Body	Radio																																																												
R	2012	ALL	Body	Rear HVAC/RSA																																																												
R	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2012	ALL	Body	Theft Deterrent Module																																																												
R	2013	ALL	Powertrain	Engine Control Module																																																												
R	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
R	2013	ALL	Powertrain	Transmission Control Module																																																												
R	2013	ALL	Chassis	Electronic Brake Control Module																																																												
R	2013	ALL	Body	Body Control Module																																																												
R	2013	ALL	Body	Digital Radio Receiver																																																												
R	2013	ALL	Body	Driver Door Switch																																																												
R	2013	ALL	Body	Head Up Display																																																												
R	2013	ALL	Body	Heated Seat Module																																																												
R	2013	ALL	Body	HVAC Control Module Auto																																																												
R	2013	ALL	Body	HVAC Control Module Manual																																																												
R	2013	ALL	Body	Instrument Panel Cluster																																																												
R	2013	ALL	Body	Left Side Object Detection Module																																																												
R	2013	ALL	Body	Lift Gate Module																																																												
R	2013	ALL	Body	Park Assist Module																																																												
R	2013	ALL	Body	Passenger Door Switch																																																												
R	2013	ALL	Body	Passenger Presence System																																																												
R	2013	ALL	Body	Radio																																																												
R	2013	ALL	Body	Rear HVAC/RSA																																																												
R	2013	ALL	Body	Right Side Object Detection Module																																																												
R	2013	ALL	Body	Supplemental Inflatable Restraint																																																												
R	2013	ALL	Body	Theft Deterrent Module																																																												
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
R	2014	Acadia	Powertrain	Chassis Control Module																																																												
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
R	2014	Acadia	Chassis	Electronic Brake Control Module																																																												
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
R	2014	Acadia	Body	Passenger Presence Module																																																												
R	2014	Acadia	Body	Instrument Cluster																																																												
R	2014	Acadia	Body	Head-Up Display Module																																																												
R	2014	Acadia	Body	Radio																																																												
R	2014	Acadia	Body	Rear Audio Control Module																																																												
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																																												
R	2014	Acadia	Body	Personal Audio Link Control Module																																																												
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																												
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																												
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																												
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																												
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
R	2014	Acadia	Body	Liftgate Control Module																																																																
R	2014	Acadia	Body	Seat Memory Control Module																																																																
R	2014	Acadia	Body	Front Seat Heating Control Module																																																																
R	2014	Acadia	Body	Right Side Object Detection Control Module																																																																
R	2014	Acadia	Body	Left Side Object Detection Control Module																																																																
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																																																
R	2014	Acadia	Body	Parking Assist Control Module																																																																
R	2014	Acadia	Body	Frontview Camera Module																																																																
R	2014	Acadia	Body	Theft Deterrent Module																																																																
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																																
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																																
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																																
R	2015	Acadia	Chassis	Electronic Brake Control Module																																																																
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																																
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																																
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
R	2015	Acadia	Body	Passenger Presence Module																																																																
R	2015	Acadia	Body	Instrument Cluster																																																																
R	2015	Acadia	Body	Head-Up Display Module																																																																
R	2015	Acadia	Body	Radio																																																																
R	2015	Acadia	Body	Rear Audio Control Module																																																																
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																																																
R	2015	Acadia	Body	Personal Audio Link Control Module																																																																
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																																
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																																
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																																
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																																
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																																
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																																
R	2015	Acadia	Body	Liftgate Control Module																																																																
R	2015	Acadia	Body	Seat Memory Control Module																																																																
R	2015	Acadia	Body	Front Seat Heating Control Module																																																																
R	2015	Acadia	Body	Right Side Object Detection Control Module																																																																
R	2015	Acadia	Body	Left Side Object Detection Control Module																																																																
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																																																
R	2015	Acadia	Body	Parking Assist Control Module																																																																
R	2015	Acadia	Body	Frontview Camera Module																																																																
R	2015	Acadia	Body	Theft Deterrent Module																																																																
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																																
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																																
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																																
R	2016	Acadia	Chassis	Electronic Brake Control Module																																																																
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																																
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																															
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																																
R	2016	Acadia	Body	Passenger Presence Module																																																																
R	2016	Acadia	Body	Instrument Cluster																																																																
R	2016	Acadia	Body	Head-Up Display Module																																																																
R	2016	Acadia	Body	Radio																																																																
R	2016	Acadia	Body	Rear Audio Control Module																																																																
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
R	2016	Acadia	Body	Personal Audio Link Control Module																																																														
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																																														
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																														
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																														
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																														
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																														
R	2016	Acadia	Body	Liftgate Control Module																																																														
R	2016	Acadia	Body	Seat Memory Control Module																																																														
R	2016	Acadia	Body	Front Seat Heating Control Module																																																														
R	2016	Acadia	Body	Right Side Object Detection Control Module																																																														
R	2016	Acadia	Body	Left Side Object Detection Control Module																																																														
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																																														
R	2016	Acadia	Body	Parking Assist Control Module																																																														
R	2016	Acadia	Body	Frontview Camera Module																																																														
R	2016	Acadia	Body	Theft Deterrent Module																																																														
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																																														
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																														
S	2004	Sonoma	Body	Body Control Module																																													V	V	V	V												
S	2004	Sonoma	Body	Instrument Panel Cluster																																																														
S	2004	Sonoma	Body	Base Radio																																																														
S	2004	Sonoma	Body	Uplevel Radio																																																														
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																														
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																														
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																														
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																														
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																														
S	2004	Canyon	Chassis	ABS Without Traction Control																																																														
S	2004	Canyon	Chassis	ABS With Traction Control																																																														
S	2004	Canyon	Body	Body Control Module																																																V													
S	2004	Canyon	Body	Instrument Panel Cluster																																																														
S	2004	Canyon	Body	OnStar																																																														
S	2004	Canyon	Body	Base Radio																																																														
S	2004	Canyon	Body	Uplevel Radio																																																														
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																																														
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2004	Envoy	Chassis	ABS Without Traction Control																																																														
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																														
S	2004	Envoy	Body	Amplifier (Bose)																																																														
S	2004	Envoy	Body	Body Control Module																																																														
S	2004	Envoy	Body	Driver Door Module																																																														
S	2004	Envoy	Body	Driver Seat Module																																																														
S	2004	Envoy	Body	Heating and Air Conditioning Auto																																																														
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																																														
S	2004	Envoy	Body	Instrument Panel Cluster																																																														
S	2004	Envoy	Body	Lift Gate Module																																																														
S	2004	Envoy	Body	OnStar																																																														
S	2004	Envoy	Body	Passenger Door Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2004	Envoy	Body	Uplevel Radio																																																											
S	2004	Envoy	Body	Navigation Radio																																																												
S	2004	Envoy	Body	Rear Seat Audio																																																												
S	2004	Envoy	Body	Rear Seat Entertainment																																																												
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2004	Envoy	Body	Vehicle Theft Deterrent																																																												
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																												
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																												
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																																												
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																												
S	2004	Envoy XL	Body	Amplifier (Bose)																																																												
S	2004	Envoy XL	Body	Body Control Module																																																												
S	2004	Envoy XL	Body	Driver Door Module																																																												
S	2004	Envoy XL	Body	Driver Seat Module																																																												
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
S	2004	Envoy XL	Body	Instrument Panel Cluster																																																												
S	2004	Envoy XL	Body	Lift Gate Module																																																												
S	2004	Envoy XL	Body	OnStar																																																												
S	2004	Envoy XL	Body	Passenger Door Module																																																												
S	2004	Envoy XL	Body	Uplevel Radio																																																												
S	2004	Envoy XL	Body	Navigation Radio																																																												
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
S	2004	Envoy XL	Body	Rear HVAC Manual																																																												
S	2004	Envoy XL	Body	Rear Seat Entertainment																																																												
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																												
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																												
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																												
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																												
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																												
S	2004	Envoy XUV	Body	Amplifier (Bose)																																																												
S	2004	Envoy XUV	Body	Body Control Module																																																												
S	2004	Envoy XUV	Body	Driver Door Module																																																												
S	2004	Envoy XUV	Body	Driver Seat Module																																																												
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																												
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																												
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																																												
S	2004	Envoy XUV	Body	Lift Gate Module																																																												
S	2004	Envoy XUV	Body	OnStar																																																												
S	2004	Envoy XUV	Body	Passenger Door Module																																																												
S	2004	Envoy XUV	Body	Uplevel Radio																																																												
S	2004	Envoy XUV	Body	Navigation Radio																																																												
S	2004	Envoy XUV	Body	Rear Seat Audio																																																												
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																											
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																											
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																											
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																											
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																																											
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																											
S	2004	Jimmy	Body	Body Control Module																																										V	V	V	V												
S	2004	Jimmy	Body	Heating and Air Conditioning																																																											
S	2004	Jimmy	Body	Instrument Panel Cluster																																																											
S	2004	Jimmy	Body	Memory Seat Module																																																											
S	2004	Jimmy	Body	Base Radio																																																											
S	2004	Jimmy	Body	Uplevel Radio																																																											
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																											
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																											
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																											
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																											
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																											
S	2005	Canyon	Chassis	ABS Without Traction Control																																																											
S	2005	Canyon	Chassis	ABS With Traction Control																																																											
S	2005	Canyon	Body	Body Control Module																																													V														
S	2005	Canyon	Body	Instrument Panel Cluster																																																											
S	2005	Canyon	Body	Base Radio																																																											
S	2005	Canyon	Body	Uplevel Radio																																																											
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																																											
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2005	Envoy	Chassis	ABS Without Traction Control																																																											
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																											
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																											
S	2005	Envoy	Body	Body Control Module																																																											
S	2005	Envoy	Body	Disc Player and Video Display																																																											
S	2005	Envoy	Body	Driver Door Module																																																											
S	2005	Envoy	Body	Driver Seat Module																																																											
S	2005	Envoy	Body	Heating and Air Conditioning Auto																																																											
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																																											
S	2005	Envoy	Body	Instrument Panel Cluster																																																											
S	2005	Envoy	Body	Lift Gate Module																																																											
S	2005	Envoy	Body	Passenger Door Module																																																											
S	2005	Envoy	Body	Passenger Presence System																																																											
S	2005	Envoy	Body	Uplevel Radio																																																											
S	2005	Envoy	Body	Navigation Radio																																																											
S	2005	Envoy	Body	Rear Seat Audio																																																											
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																																											
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																																											
S	2005	Envoy	Body	Vehicle Theft Deterrent																																																											
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																												
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																																													
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																													
S	2005	Envoy XL	Body	Body Control Module																																																													
S	2005	Envoy XL	Body	Disc Player and Video Display																																																													
S	2005	Envoy XL	Body	Driver Door Module																																																													
S	2005	Envoy XL	Body	Driver Seat Module																																																													
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																													
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																													
S	2005	Envoy XL	Body	Instrument Panel Cluster																																																													
S	2005	Envoy XL	Body	Lift Gate Module																																																													
S	2005	Envoy XL	Body	Passenger Door Module																																																													
S	2005	Envoy XL	Body	Passenger Presence System																																																													
S	2005	Envoy XL	Body	Uplevel Radio																																																													
S	2005	Envoy XL	Body	Navigation Radio																																																													
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																													
S	2005	Envoy XL	Body	Rear HVAC Manual																																																													
S	2005	Envoy XL	Body	Rear Seat Audio																																																													
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																													
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																													
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																													
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																													
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																													
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																													
S	2005	Envoy XUV	Body	Body Control Module																																																													
S	2005	Envoy XUV	Body	Disc Player and Video Display																																																													
S	2005	Envoy XUV	Body	Driver Door Module																																																													
S	2005	Envoy XUV	Body	Driver Seat Module																																																													
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																													
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																													
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																																													
S	2005	Envoy XUV	Body	Lift Gate Module																																																													
S	2005	Envoy XUV	Body	Passenger Door Module																																																													
S	2005	Envoy XUV	Body	Passenger Presence System																																																													
S	2005	Envoy XUV	Body	Uplevel Radio																																																													
S	2005	Envoy XUV	Body	Navigation Radio																																																													
S	2005	Envoy XUV	Body	Rear Seat Audio																																																													
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																													
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																													
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																													
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																																													
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																													
S	2005	Jimmy	Body	Body Control Module																																																													
S	2005	Jimmy	Body	Heating and Air Conditioning																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2005	Jimmy	Body	Instrument Panel Cluster																																																														
S	2005	Jimmy	Body	Memory Seat Module																																																														
S	2005	Jimmy	Body	Base Radio																																																														
S	2005	Jimmy	Body	Uplevel Radio																																																														
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																														
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																																														
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																														
S	2005	Sonoma	Body	Body Control Module																																																					V	V	V	V								
S	2005	Sonoma	Body	Instrument Panel Cluster																																																														
S	2005	Sonoma	Body	Base Radio																																																														
S	2005	Sonoma	Body	Uplevel Radio																																																														
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																														
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																														
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																														
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																														
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																														
S	2006	Canyon	Chassis	ABS Without Traction Control																																																														
S	2006	Canyon	Chassis	ABS With Traction Control																																																														
S	2006	Canyon	Body	Body Control Module																																																						V									
S	2006	Canyon	Body	Instrument Panel Cluster																																																														
S	2006	Canyon	Body	Passenger Presence System																																																														
S	2006	Canyon	Body	Base Radio																																																														
S	2006	Canyon	Body	Uplevel Radio																																																														
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																																														
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																																														
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																														
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
S	2006	Envoy	Chassis	ABS/TCS/VSES																																																														
S	2006	Envoy	Chassis	Tire Pressure Monitor																																																														
S	2006	Envoy	Body	Body Control Module																																																														
S	2006	Envoy	Body	Disc Player and Video Display																																																														
S	2006	Envoy	Body	Driver Door Module																																																														
S	2006	Envoy	Body	Driver Seat Module																																																														
S	2006	Envoy	Body	Heating and Air Conditioning Auto																																																														
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																																														
S	2006	Envoy	Body	Instrument Panel Cluster																																																														
S	2006	Envoy	Body	Lift Gate Module																																																														
S	2006	Envoy	Body	Passenger Door Module																																																														
S	2006	Envoy	Body	Passenger Presence System																																																														
S	2006	Envoy	Body	Uplevel Radio																																																														
S	2006	Envoy	Body	Navigation Radio																																																														
S	2006	Envoy	Body	Rear Seat Audio																																																														
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																																														
S	2006	Envoy	Body	Vehicle Theft Deterrent																																																														
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																													
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																													
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																													
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																													
S	2006	Envoy XL	Body	Body Control Module																																																													
S	2006	Envoy XL	Body	Disc Player and Video Display																																																													
S	2006	Envoy XL	Body	Driver Door Module																																																													
S	2006	Envoy XL	Body	Driver Seat Module																																																													
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																													
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																													
S	2006	Envoy XL	Body	Instrument Panel Cluster																																																													
S	2006	Envoy XL	Body	Lift Gate Module																																																													
S	2006	Envoy XL	Body	Passenger Door Module																																																													
S	2006	Envoy XL	Body	Passenger Presence System																																																													
S	2006	Envoy XL	Body	Uplevel Radio																																																													
S	2006	Envoy XL	Body	Navigation Radio																																																													
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																													
S	2006	Envoy XL	Body	Rear HVAC Manual																																																													
S	2006	Envoy XL	Body	Rear Seat Audio																																																													
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																													
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																													
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																													
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																													
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																													
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																													
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																													
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																													
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																													
S	2007	Canyon	Body	Body Control Module																																																						V									
S	2007	Canyon	Body	Digital Radio Receiver																																																													
S	2007	Canyon	Body	Generator Battery Control Module																																																													
S	2007	Canyon	Body	Instrument Panel Cluster																																																													
S	2007	Canyon	Body	Passenger Presence System																																																													
S	2007	Canyon	Body	Base Radio																																																													
S	2007	Canyon	Body	Uplevel Radio																																																													
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																																													
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																																													
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																														
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																														
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																														
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
S	2007	Envoy	Chassis	Electronic Brake Control Module																																																														
S	2007	Envoy	Body	Body Control Module																																																														
S	2007	Envoy	Body	Digital Radio Receiver																																																														
S	2007	Envoy	Body	Disc Player and Video Display																																																														
S	2007	Envoy	Body	Driver Door Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2007	Envoy	Body	Driver Seat Module																																																											
S	2007	Envoy	Body	Generator Battery Control Module																																																												
S	2007	Envoy	Body	HVAC Control Module Auto																																																												
S	2007	Envoy	Body	HVAC Control Module Manual																																																												
S	2007	Envoy	Body	Instrument Panel Cluster																																																												
S	2007	Envoy	Body	Lift Gate Module																																																												
S	2007	Envoy	Body	Passenger Door Module																																																												
S	2007	Envoy	Body	Passenger Presence System																																																												
S	2007	Envoy	Body	Uplevel Radio																																																												
S	2007	Envoy	Body	Navigation Radio																																																												
S	2007	Envoy	Body	Rear Seat Audio																																																												
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																																												
S	2007	Envoy	Body	Theft Deterrent Module																																																												
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																																												
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																												
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																												
S	2008	Canyon	Body	Body Control Module																																																					V								
S	2008	Canyon	Body	Digital Radio Receiver																																																												
S	2008	Canyon	Body	Generator Battery Control Module																																																												
S	2008	Canyon	Body	Instrument Panel Cluster																																																												
S	2008	Canyon	Body	Passenger Presence System																																																												
S	2008	Canyon	Body	Base Radio																																																											
S	2008	Canyon	Body	Uplevel Radio																																																											
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																																											
S	2008	Canyon	Body	Theft Deterrent Module																																																											
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																																											
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																											
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																											
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																											
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																											
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																											
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																											
S	2008	Envoy	Chassis	Electronic Brake Control Module																																																											
S	2008	Envoy	Body	Body Control Module																																																											
S	2008	Envoy	Body	Digital Radio Receiver																																																											
S	2008	Envoy	Body	Disc Player and Video Display																																																											
S	2008	Envoy	Body	Driver Door Module																																																										
S	2008	Envoy	Body	Driver Seat Module																																																											
S	2008	Envoy	Body	Generator Battery Control Module																																																											
S	2008	Envoy	Body	HVAC Control Module Auto																																																											
S	2008	Envoy	Body	HVAC Control Module Manual																																																											
S	2008	Envoy	Body	Instrument Panel Cluster																																																											
S	2008	Envoy	Body	Lift Gate Module																																																											
S	2008	Envoy	Body	Passenger Door Module																																																											
S	2008	Envoy	Body	Passenger Presence System																																																											
S	2008	Envoy	Body	Uplevel Radio																																																											
S	2008	Envoy	Body	Navigation Radio																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2008	Envoy	Body	Rear Seat Audio																																																										
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2008	Envoy	Body	Theft Deterrent Module																																																										
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																																										
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																										
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																										
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																										
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																										
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																										
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																										
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																										
S	2009	Canyon	Chassis	Electronic Brake Control Module																																																										
S	2009	Canyon	Body	Body Control Module																																																										
S	2009	Canyon	Body	Digital Radio Receiver																																																										
S	2009	Canyon	Body	Generator Battery Control Module																																																										
S	2009	Canyon	Body	Instrument Panel Cluster																																																										
S	2009	Canyon	Body	Passenger Presence System																																																										
S	2009	Canyon	Body	Base Radio																																																										
S	2009	Canyon	Body	Uplevel Radio																																																										
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																																										
S	2009	Canyon	Body	Theft Deterrent Module																																																										
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																										
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																										
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																																										
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																										
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																										
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																																										
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																										
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																										
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																																										
S	2009	Envoy	Chassis	Electronic Brake Control Module																																																										
S	2009	Envoy	Body	Body Control Module																																																										
S	2009	Envoy	Body	Digital Radio Receiver																																																										
S	2009	Envoy	Body	Disc Player and Video Display																																																										
S	2009	Envoy	Body	Driver Door Module																																																										
S	2009	Envoy	Body	Driver Seat Module																																																										
S	2009	Envoy	Body	Generator Battery Control Module																																																										
S	2009	Envoy	Body	HVAC Control Module Auto																																																										
S	2009	Envoy	Body	HVAC Control Module Manual																																																										
S	2009	Envoy	Body	Instrument Panel Cluster																																																										
S	2009	Envoy	Body	Lift Gate Module																																																										
S	2009	Envoy	Body	Passenger Door Module																																																										
S	2009	Envoy	Body	Passenger Presence System																																																										
S	2009	Envoy	Body	Uplevel Radio																																																										
S	2009	Envoy	Body	Navigation Radio																																																										
S	2009	Envoy	Body	Rear Seat Audio																																																										
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																																										
S	2009	Envoy	Body	Theft Deterrent Module																																																										
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																													
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																														
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																														
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																														
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																														
S	2010	ALL	Chassis	Electronic Brake Control Module																																																															
S	2010	ALL	Body	Body Control Module																																																						V									
S	2010	ALL	Body	Digital Radio Receiver																																																														
S	2010	ALL	Body	Generator Battery Control Module																																																															
S	2010	ALL	Body	Instument Panel Cluster																																																															
S	2010	ALL	Body	Passenger Presence System																																																															
S	2010	ALL	Body	Personal Audio Link Module																																																															
S	2010	ALL	Body	Base Radio																																																															
S	2010	ALL	Body	Uplevel Radio																																																															
S	2010	ALL	Body	Supplemental Inflatable Restraint																																																															
S	2010	ALL	Body	Theft Deterrent Module																																																															
S	2010	ALL	Body	Vehicle Comm. Interface Module																																																															
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																															
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																																															
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																																															
T	2004	Sonoma	Body	Body Control Module																																																						V	V	V	V							
T	2004	Sonoma	Body	Instrument Panel Cluster																																																															
T	2004	Sonoma	Body	Base Radio																																																															
T	2004	Sonoma	Body	Uplevel Radio																																																															
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																																															
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																															
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																															
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																															
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																															
T	2004	Canyon	Chassis	ABS Without Traction Control																																																															
T	2004	Canyon	Chassis	ABS With Traction Control																																																															
T	2004	Canyon	Body	Body Control Module																																																						V									
T	2004	Canyon	Body	Instrument Panel Cluster																																																															
T	2004	Canyon	Body	OnStar																																																															
T	2004	Canyon	Body	Base Radio																																																															
T	2004	Canyon	Body	Uplevel Radio																																																															
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																																															
T	2004	Canyon	Body	Instrument Panel Cluster																																																															
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																																															
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																															
T	2004	Envoy	Chassis	ABS Without Traction Control																																																															
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																															
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																																															
T	2004	Envoy	Body	Amplifier (Bose)																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2004	Envoy	Body	Body Control Module																																																												
T	2004	Envoy	Body	Driver Door Module																																																												
T	2004	Envoy	Body	Driver Seat Module																																																												
T	2004	Envoy	Body	Heating and Air Conditioning Auto																																																												
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																																												
T	2004	Envoy	Body	Instrument Panel Cluster																																																												
T	2004	Envoy	Body	Lift Gate Module																																																												
T	2004	Envoy	Body	OnStar																																																												
T	2004	Envoy	Body	Passenger Door Module																																																												
T	2004	Envoy	Body	Uplevel Radio																																																												
T	2004	Envoy	Body	Navigation Radio																																																												
T	2004	Envoy	Body	Rear Seat Audio																																																												
T	2004	Envoy	Body	Rear Seat Entertainment																																																												
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																																												
T	2004	Envoy	Body	Vehicle Theft Deterrent																																																												
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																												
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																												
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																												
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																																												
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																																												
T	2004	Envoy XL	Body	Amplifier (Bose)																																																												
T	2004	Envoy XL	Body	Body Control Module																																																												
T	2004	Envoy XL	Body	Driver Door Module																																																												
T	2004	Envoy XL	Body	Driver Seat Module																																																												
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto																																																												
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																																												
T	2004	Envoy XL	Body	Instrument Panel Cluster																																																												
T	2004	Envoy XL	Body	Lift Gate Module																																																												
T	2004	Envoy XL	Body	OnStar																																																												
T	2004	Envoy XL	Body	Passenger Door Module																																																												
T	2004	Envoy XL	Body	Uplevel Radio																																																												
T	2004	Envoy XL	Body	Navigation Radio																																																												
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																																												
T	2004	Envoy XL	Body	Rear HVAC Manual																																																												
T	2004	Envoy XL	Body	Rear Seat Entertainment																																																												
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																																												
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																																												
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																												
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																																												
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																																												
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																																												
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																																												
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																												
T	2004	Envoy XUV	Body	Amplifier (Bose)																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2004	Envoy XUV	Body	Body Control Module																																																												
T	2004	Envoy XUV	Body	Driver Door Module																																																												
T	2004	Envoy XUV	Body	Driver Seat Module																																																												
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto																																																												
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																																												
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																																												
T	2004	Envoy XUV	Body	Lift Gate Module																																																												
T	2004	Envoy XUV	Body	OnStar																																																												
T	2004	Envoy XUV	Body	Passenger Door Module																																																												
T	2004	Envoy XUV	Body	Uplevel Radio																																																												
T	2004	Envoy XUV	Body	Navigation Radio																																																												
T	2004	Envoy XUV	Body	Rear Seat Audio																																																												
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																																												
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																																												
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																												
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																																												
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																																												
T	2004	Jimmy	Body	Body Control Module																																										V	V	V	V													
T	2004	Jimmy	Body	Heating and Air Conditioning																																																												
T	2004	Jimmy	Body	Instrument Panel Cluster																																																												
T	2004	Jimmy	Body	Memory Seat Module																																																												
T	2004	Jimmy	Body	Base Radio																																																												
T	2004	Jimmy	Body	Uplevel Radio																																																												
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																																												
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																												
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																												
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																												
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																												
T	2005	Canyon	Chassis	ABS Without Traction Control																																																												
T	2005	Canyon	Chassis	ABS With Traction Control																																																												
T	2005	Canyon	Body	Body Control Module																																													V															
T	2005	Canyon	Body	Instrument Panel Cluster																																																												
T	2005	Canyon	Body	Base Radio																																																												
T	2005	Canyon	Body	Uplevel Radio																																																												
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																																												
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																												
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																											V																	
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																																												
T	2005	Envoy	Chassis	ABS Without Traction Control																																																												
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																												
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																																												
T	2005	Envoy	Body	Body Control Module																																																												
T	2005	Envoy	Body	Disc Player and Video Display																																																												
T	2005	Envoy	Body	Driver Door Module																																																												
T	2005	Envoy	Body	Driver Seat Module																																																												
T	2005	Envoy	Body	Heating and Air Conditioning Auto																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																																													
T	2005	Envoy	Body	Instrument Panel Cluster																																																														
T	2005	Envoy	Body	Lift Gate Module																																																														
T	2005	Envoy	Body	Passenger Door Module																																																														
T	2005	Envoy	Body	Passenger Presence System																																																														
T	2005	Envoy	Body	Uplevel Radio																																																														
T	2005	Envoy	Body	Navigation Radio																																																														
T	2005	Envoy	Body	Rear Seat Audio																																																														
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																																														
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																																														
T	2005	Envoy	Body	Vehicle Theft Deterrent																																																														
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																														
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																														
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																																														
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																																														
T	2005	Envoy XL	Body	Body Control Module																																																														
T	2005	Envoy XL	Body	Disc Player and Video Display																																																														
T	2005	Envoy XL	Body	Driver Door Module																																																														
T	2005	Envoy XL	Body	Driver Seat Module																																																														
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto																																																														
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																																														
T	2005	Envoy XL	Body	Instrument Panel Cluster																																																														
T	2005	Envoy XL	Body	Lift Gate Module																																																														
T	2005	Envoy XL	Body	Passenger Door Module																																																														
T	2005	Envoy XL	Body	Passenger Presence System																																																														
T	2005	Envoy XL	Body	Uplevel Radio																																																														
T	2005	Envoy XL	Body	Navigation Radio																																																														
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																																														
T	2005	Envoy XL	Body	Rear HVAC Manual																																																														
T	2005	Envoy XL	Body	Rear Seat Audio																																																														
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																																														
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																																														
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																																														
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																														
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																														
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																																														
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																																														
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																																														
T	2005	Envoy XUV	Body	Body Control Module																																																														
T	2005	Envoy XUV	Body	Disc Player and Video Display																																																														
T	2005	Envoy XUV	Body	Driver Door Module																																																														
T	2005	Envoy XUV	Body	Driver Seat Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto																																																														
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																																														
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																																														
T	2005	Envoy XUV	Body	Lift Gate Module																																																														
T	2005	Envoy XUV	Body	Passenger Door Module																																																														
T	2005	Envoy XUV	Body	Passenger Presence System																																																														
T	2005	Envoy XUV	Body	Uplevel Radio																																																														
T	2005	Envoy XUV	Body	Navigation Radio																																																														
T	2005	Envoy XUV	Body	Rear Seat Audio																																																														
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																																														
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																																														
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																																														
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																														
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																																														
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																																														
T	2005	Jimmy	Body	Body Control Module																																																					V	V	V	V								
T	2005	Jimmy	Body	Heating and Air Conditioning																																																															
T	2005	Jimmy	Body	Instrument Panel Cluster																																																															
T	2005	Jimmy	Body	Memory Seat Module																																																															
T	2005	Jimmy	Body	Base Radio																																																															
T	2005	Jimmy	Body	Uplevel Radio																																																															
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																																															
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																															
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																															
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																																															
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																																															
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																																															
T	2005	Sonoma	Body	Body Control Module																																																				V	V	V	V								
T	2005	Sonoma	Body	Instrument Panel Cluster																																																															
T	2005	Sonoma	Body	Base Radio																																																															
T	2005	Sonoma	Body	Uplevel Radio																																																															
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																																															
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																																															
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																																															
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																																															
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																																															
T	2006	Canyon	Chassis	ABS Without Traction Control																																																															
T	2006	Canyon	Chassis	ABS With Traction Control																																																															
T	2006	Canyon	Body	Body Control Module																																																						V										
T	2006	Canyon	Body	Instrument Panel Cluster																																																															
T	2006	Canyon	Body	Passenger Presence System																																																															
T	2006	Canyon	Body	Base Radio																																																															
T	2006	Canyon	Body	Uplevel Radio																																																															
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																																															
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																																															
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																															
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																													
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																															
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																															
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																															
T	2006	Envoy	Chassis	ABS/TCS/VSES																																																															
T	2006	Envoy	Chassis	Tire Pressure Monitor																																																															
T	2006	Envoy	Body	Body Control Module																																																															
T	2006	Envoy	Body	Disc Player and Video Display																																																															
T	2006	Envoy	Body	Driver Door Module																																																															
T	2006	Envoy	Body	Driver Seat Module																																																															
T	2006	Envoy	Body	Heating and Air Conditioning Auto																																																															
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																																															
T	2006	Envoy	Body	Instrument Panel Cluster																																																															
T	2006	Envoy	Body	Lift Gate Module																																																															
T	2006	Envoy	Body	Passenger Door Module																																																															
T	2006	Envoy	Body	Passenger Presence System																																																															
T	2006	Envoy	Body	Uplevel Radio																																																															
T	2006	Envoy	Body	Navigation Radio																																																															
T	2006	Envoy	Body	Rear Seat Audio																																																															
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																																															
T	2006	Envoy	Body	Vehicle Theft Deterrent																																																															
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																																															
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																															
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																															
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																																															
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																															
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																															
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																																															
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																																															
T	2006	Envoy XL	Body	Body Control Module																																																															
T	2006	Envoy XL	Body	Disc Player and Video Display																																																															
T	2006	Envoy XL	Body	Driver Door Module																																																															
T	2006	Envoy XL	Body	Driver Seat Module																																																															
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto																																																															
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																																															
T	2006	Envoy XL	Body	Instrument Panel Cluster																																																															
T	2006	Envoy XL	Body	Lift Gate Module																																																															
T	2006	Envoy XL	Body	Passenger Door Module																																																															
T	2006	Envoy XL	Body	Passenger Presence System																																																															
T	2006	Envoy XL	Body	Uplevel Radio																																																															
T	2006	Envoy XL	Body	Navigation Radio																																																															
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																																															
T	2006	Envoy XL	Body	Rear HVAC Manual																																																															
T	2006	Envoy XL	Body	Rear Seat Audio																																																															
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																																															
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																																															
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																																															
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																															
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																															
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																															
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																															
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																																
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																																																
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																																																
T	2007	Canyon	Body	Body Control Module																																																					V											
T	2007	Canyon	Body	Digital Radio Receiver																																																															
T	2007	Canyon	Body	Generator Battery Control Module																																																																
T	2007	Canyon	Body	Instrument Panel Cluster																																																																
T	2007	Canyon	Body	Passenger Presence System																																																																
T	2007	Canyon	Body	Base Radio																																																																
T	2007	Canyon	Body	Uplevel Radio																																																																
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																																																
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																																																
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																																
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																																
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																																
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																																																
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																																																
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																																																
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																																
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																																
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																																
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																																
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																																
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																																																
T	2007	Envoy	Chassis	Electronic Brake Control Module																																																																
T	2007	Envoy	Body	Body Control Module																																																																
T	2007	Envoy	Body	Digital Radio Receiver																																																																
T	2007	Envoy	Body	Disc Player and Video Display																																																																
T	2007	Envoy	Body	Driver Door Module																																																																
T	2007	Envoy	Body	Driver Seat Module																																																																
T	2007	Envoy	Body	Generator Battery Control Module																																																																
T	2007	Envoy	Body	HVAC Control Module Auto																																																																
T	2007	Envoy	Body	HVAC Control Module Manual																																																																
T	2007	Envoy	Body	Instrument Panel Cluster																																																																
T	2007	Envoy	Body	Lift Gate Module																																																																
T	2007	Envoy	Body	Passenger Door Module																																																																
T	2007	Envoy	Body	Passenger Presence System																																																																
T	2007	Envoy	Body	Uplevel Radio																																																																
T	2007	Envoy	Body	Navigation Radio																																																																
T	2007	Envoy	Body	Rear Seat Audio																																																																
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																																																
T	2007	Envoy	Body	Theft Deterrent Module																																																																
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																																																
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																																
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																																
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																																
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																																
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																																
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																																
T	2008	Canyon	Chassis	Electronic Brake Control Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2008	Canyon	Body	Body Control Module																																															V										
T	2008	Canyon	Body	Digital Radio Receiver																																																								
T	2008	Canyon	Body	Generator Battery Control Module																																																								
T	2008	Canyon	Body	Instrument Panel Cluster																																																								
T	2008	Canyon	Body	Passenger Presence System																																																								
T	2008	Canyon	Body	Base Radio																																																								
T	2008	Canyon	Body	Uplevel Radio																																																								
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																																								
T	2008	Canyon	Body	Theft Deterrent Module																																																								
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																																								
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																								
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																								
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																		V										
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																								
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																								
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																		V										
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																								
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																								
T	2008	Envoy	Chassis	Electronic Brake Control Module																																																								
T	2008	Envoy	Body	Body Control Module																																																								
T	2008	Envoy	Body	Digital Radio Receiver																																																								
T	2008	Envoy	Body	Disc Player and Video Display																																																								
T	2008	Envoy	Body	Driver Door Module																																																								
T	2008	Envoy	Body	Driver Seat Module																																																								
T	2008	Envoy	Body	Generator Battery Control Module																																																								
T	2008	Envoy	Body	HVAC Control Module Auto																																																								
T	2008	Envoy	Body	HVAC Control Module Manual																																																								
T	2008	Envoy	Body	Instrument Panel Cluster																																																								
T	2008	Envoy	Body	Lift Gate Module																																																								
T	2008	Envoy	Body	Passenger Door Module																																																								
T	2008	Envoy	Body	Passenger Presence System																																																								
T	2008	Envoy	Body	Uplevel Radio																																																								
T	2008	Envoy	Body	Navigation Radio																																																								
T	2008	Envoy	Body	Rear Seat Audio																																																								
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																																								
T	2008	Envoy	Body	Theft Deterrent Module																																																								
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																																								
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																								
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																								
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																								
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																								
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																								
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																								
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																								
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																								
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																																								
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																																								
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																																								
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																																								
T	2009	Canyon	Chassis	Electronic Brake Control Module																																																								
T	2009	Canyon	Body	Body Control Module																																																								

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2009	Canyon	Body	Digital Radio Receiver																																																													
T	2009	Canyon	Body	Generator Battery Control Module																																																														
T	2009	Canyon	Body	Instrument Panel Cluster																																																														
T	2009	Canyon	Body	Passenger Presence System																																																														
T	2009	Canyon	Body	Base Radio																																																														
T	2009	Canyon	Body	Uplevel Radio																																																														
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																																														
T	2009	Canyon	Body	Theft Deterrent Module																																																														
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																																														
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																																														
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																																														
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																																														
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																																														
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																																														
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																																														
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																																														
T	2009	Envoy	Chassis	Electronic Brake Control Module																																																														
T	2009	Envoy	Body	Body Control Module																																																														
T	2009	Envoy	Body	Digital Radio Receiver																																																														
T	2009	Envoy	Body	Disc Player and Video Display																																																														
T	2009	Envoy	Body	Driver Door Module																																																														
T	2009	Envoy	Body	Driver Seat Module																																																														
T	2009	Envoy	Body	Generator Battery Control Module																																																														
T	2009	Envoy	Body	HVAC Control Module Auto																																																														
T	2009	Envoy	Body	HVAC Control Module Manual																																																														
T	2009	Envoy	Body	Instrument Panel Cluster																																																														
T	2009	Envoy	Body	Lift Gate Module																																																														
T	2009	Envoy	Body	Passenger Door Module																																																														
T	2009	Envoy	Body	Passenger Presence System																																																														
T	2009	Envoy	Body	Uplevel Radio																																																														
T	2009	Envoy	Body	Navigation Radio																																																														
T	2009	Envoy	Body	Rear Seat Audio																																																														
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																																														
T	2009	Envoy	Body	Theft Deterrent Module																																																														
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																														
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																														
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																														
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																														
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																														
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																														
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																														
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																														
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																														
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																														
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																														
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																														
T	2010	ALL	Chassis	Electronic Brake Control Module																																																														
T	2010	ALL	Body	Body Control Module																																																														
T	2010	ALL	Body	Digital Radio Receiver																																																														
T	2010	ALL	Body	Generator Battery Control Module																																																														
T	2010	ALL	Body	Instrument Panel Cluster																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
T	2010	ALL	Body	Passenger Presence System																																																											
T	2010	ALL	Body	Personal Audio Link Module																																																												
T	2010	ALL	Body	Base Radio																																																												
T	2010	ALL	Body	Uplevel Radio																																																												
T	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
T	2010	ALL	Body	Theft Deterrent Module																																																												
T	2010	ALL	Body	Vehicle Comm. Interface Module																																																												
V	2007	ALL	Powertrain	Engine Control Module																																																												
V	2007	ALL	Powertrain	Rear Drive System																																																												
V	2007	ALL	Powertrain	Transmission Control Module																																																												
V	2007	ALL	Chassis	Electronic Brake Control Module																																																												
V	2007	ALL	Body	Body Control Module																																																												
V	2007	ALL	Body	Digital Radio Receiver																																																												
V	2007	ALL	Body	Driver Door Switch																																																												
V	2007	ALL	Body	Head Up Display																																																												
V	2007	ALL	Body	Heated Seat Module																																																												
V	2007	ALL	Body	HVAC Control Module Auto																																																												
V	2007	ALL	Body	HVAC Control Module Manual																																																												
V	2007	ALL	Body	Instrument Panel Cluster																																																												
V	2007	ALL	Body	Lift Gate Module																																																												
V	2007	ALL	Body	Park Assist Module																																																												
V	2007	ALL	Body	Passenger Door Switch																																																												
V	2007	ALL	Body	Passenger Presence System																																																												
V	2007	ALL	Body	Radio																																																												
V	2007	ALL	Body	Rear HVAC/RSA																																																												
V	2007	ALL	Body	Rollover Sensor																																																												
V	2007	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2007	ALL	Body	Theft Deterrent Module																																																												
V	2008	ALL	Powertrain	Engine Control Module																																																												
V	2008	ALL	Powertrain	Rear Drive System																																																												
V	2008	ALL	Powertrain	Transmission Control Module																																																												
V	2008	ALL	Chassis	Electronic Brake Control Module																																																												
V	2008	ALL	Body	Body Control Module																																																												
V	2008	ALL	Body	Digital Radio Receiver																																																												
V	2008	ALL	Body	Driver Door Switch																																																												
V	2008	ALL	Body	Head Up Display																																																												
V	2008	ALL	Body	Heated Seat Module																																																												
V	2008	ALL	Body	HVAC Control Module Auto																																																												
V	2008	ALL	Body	HVAC Control Module Manual																																																												
V	2008	ALL	Body	Instrument Panel Cluster																																																												
V	2008	ALL	Body	Lift Gate Module																																																												
V	2008	ALL	Body	Park Assist Module																																																												
V	2008	ALL	Body	Passenger Door Switch																																																												
V	2008	ALL	Body	Passenger Presence System																																																												
V	2008	ALL	Body	Radio																																																												
V	2008	ALL	Body	Rear HVAC/RSA																																																												
V	2008	ALL	Body	Rollover Sensor																																																												
V	2008	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2008	ALL	Body	Theft Deterrent Module																																																												
V	2009	ALL	Powertrain	Engine Control Module																																																												
V	2009	ALL	Powertrain	Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
V	2009	ALL	Powertrain	Rear Drive System																																																											
V	2009	ALL	Powertrain	Transmission Control Module																																																												
V	2009	ALL	Chassis	Electronic Brake Control Module																																																												
V	2009	ALL	Body	Body Control Module																																																												
V	2009	ALL	Body	Digital Radio Receiver																																																												
V	2009	ALL	Body	Driver Door Switch																																																												
V	2009	ALL	Body	Head Up Display																																																												
V	2009	ALL	Body	Heated Seat Module																																																												
V	2009	ALL	Body	HVAC Control Module Auto																																																												
V	2009	ALL	Body	HVAC Control Module Manual																																																												
V	2009	ALL	Body	Instrument Panel Cluster																																																												
V	2009	ALL	Body	Lift Gate Module																																																												
V	2009	ALL	Body	Park Assist Module																																																												
V	2009	ALL	Body	Passenger Door Switch																																																												
V	2009	ALL	Body	Passenger Presence System																																																												
V	2009	ALL	Body	Radio																																																												
V	2009	ALL	Body	Rear HVAC/RSA																																																												
V	2009	ALL	Body	Rollover Sensor																																																												
V	2009	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2009	ALL	Body	Theft Deterrent Module																																																												
V	2010	ALL	Powertrain	Engine Control Module																																																												
V	2010	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2010	ALL	Powertrain	Rear Drive System																																																												
V	2010	ALL	Powertrain	Transmission Control Module																																																												
V	2010	ALL	Chassis	Electronic Brake Control Module																																																												
V	2010	ALL	Body	Body Control Module																																																												
V	2010	ALL	Body	Digital Radio Receiver																																																												
V	2010	ALL	Body	Driver Door Switch																																																												
V	2010	ALL	Body	Head Up Display																																																												
V	2010	ALL	Body	Heated Seat Module																																																												
V	2010	ALL	Body	HVAC Control Module Auto																																																												
V	2010	ALL	Body	HVAC Control Module Manual																																																												
V	2010	ALL	Body	Instrument Panel Cluster																																																												
V	2010	ALL	Body	Lift Gate Module																																																												
V	2010	ALL	Body	Park Assist Module																																																												
V	2010	ALL	Body	Passenger Door Switch																																																												
V	2010	ALL	Body	Passenger Presence System																																																												
V	2010	ALL	Body	Radio																																																												
V	2010	ALL	Body	Rear HVAC/RSA																																																												
V	2010	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2010	ALL	Body	Theft Deterrent Module																																																												
V	2011	ALL	Powertrain	Engine Control Module																																																												
V	2011	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2011	ALL	Powertrain	Rear Drive System																																																												
V	2011	ALL	Powertrain	Transmission Control Module																																																												
V	2011	ALL	Chassis	Electronic Brake Control Module																																																												
V	2011	ALL	Body	Body Control Module																																																												
V	2011	ALL	Body	Digital Radio Receiver																																																												
V	2011	ALL	Body	Driver Door Switch																																																												
V	2011	ALL	Body	Head Up Display																																																												
V	2011	ALL	Body	Heated Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
V	2011	ALL	Body	HVAC Control Module Auto																																																											
V	2011	ALL	Body	HVAC Control Module Manual																																																												
V	2011	ALL	Body	Instrument Panel Cluster																																																												
V	2011	ALL	Body	Lift Gate Module																																																												
V	2011	ALL	Body	Park Assist Module																																																												
V	2011	ALL	Body	Passenger Door Switch																																																												
V	2011	ALL	Body	Passenger Presence System																																																												
V	2011	ALL	Body	Radio																																																												
V	2011	ALL	Body	Rear HVAC/RSA																																																												
V	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2011	ALL	Body	Theft Deterrent Module																																																												
V	2012	ALL	Powertrain	Engine Control Module																																																												
V	2012	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2012	ALL	Powertrain	Rear Drive System																																																												
V	2012	ALL	Powertrain	Transmission Control Module																																																												
V	2012	ALL	Chassis	Electronic Brake Control Module																																																												
V	2012	ALL	Body	Body Control Module																																																												
V	2012	ALL	Body	Digital Radio Receiver																																																												
V	2012	ALL	Body	Driver Door Switch																																																												
V	2012	ALL	Body	Head Up Display																																																												
V	2012	ALL	Body	Heated Seat Module																																																												
V	2012	ALL	Body	HVAC Control Module Auto																																																												
V	2012	ALL	Body	HVAC Control Module Manual																																																												
V	2012	ALL	Body	Instrument Panel Cluster																																																												
V	2012	ALL	Body	Lift Gate Module																																																												
V	2012	ALL	Body	Park Assist Module																																																												
V	2012	ALL	Body	Passenger Door Switch																																																												
V	2012	ALL	Body	Passenger Presence System																																																												
V	2012	ALL	Body	Radio																																																												
V	2012	ALL	Body	Rear HVAC/RSA																																																												
V	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
V	2012	ALL	Body	Theft Deterrent Module																																																												
V	2013	ALL	Powertrain	Engine Control Module																																																												
V	2013	ALL	Powertrain	Fuel Pump Control Module																																																												
V	2013	ALL	Powertrain	Rear Drive System																																																												
V	2013	ALL	Powertrain	Transmission Control Module																																																												
V	2013	ALL	Chassis	Electronic Brake Control Module																																																												
V	2013	ALL	Body	Body Control Module																																																												
V	2013	ALL	Body	Digital Radio Receiver																																																												
V	2013	ALL	Body	Driver Door Switch																																																												
V	2013	ALL	Body	Head Up Display																																																												
V	2013	ALL	Body	Heated Seat Module																																																												
V	2013	ALL	Body	HVAC Control Module Auto																																																												
V	2013	ALL	Body	HVAC Control Module Manual																																																												
V	2013	ALL	Body	Instrument Panel Cluster																																																												
V	2013	ALL	Body	Left Side Object Detection Module																																																												
V	2013	ALL	Body	Lift Gate Module																																																												
V	2013	ALL	Body	Park Assist Module																																																												
V	2013	ALL	Body	Passenger Door Switch																																																												
V	2013	ALL	Body	Passenger Presence System																																																												
V	2013	ALL	Body	Radio																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
V	2013	ALL	Body	Rear HVAC/RSA																																																														
V	2013	ALL	Body	Right Side Object Detection Module																																																														
V	2013	ALL	Body	Supplemental Inflatable Restraint																																																														
V	2013	ALL	Body	Theft Deterrent Module																																																														
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																														
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																														
V	2014	Acadia	Powertrain	Chassis Control Module																																																														
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																																														
V	2014	Acadia	Chassis	Electronic Brake Control Module																																																														
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																																														
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																														
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
V	2014	Acadia	Body	Passenger Presence Module																																																															
V	2014	Acadia	Body	Instrument Cluster																																																															
V	2014	Acadia	Body	Head-Up Display Module																																																															
V	2014	Acadia	Body	Radio																																																															
V	2014	Acadia	Body	Rear Audio Control Module																																																															
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																																															
V	2014	Acadia	Body	Personal Audio Link Control Module																																																															
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																															
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																															
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																															
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																																															
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																																															
V	2014	Acadia	Body	Liftgate Control Module																																																															
V	2014	Acadia	Body	Seat Memory Control Module																																																															
V	2014	Acadia	Body	Front Seat Heating Control Module																																																															
V	2014	Acadia	Body	Right Side Object Detection Control Module																																																															
V	2014	Acadia	Body	Left Side Object Detection Control Module																																																															
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																																															
V	2014	Acadia	Body	Parking Assist Control Module																																																															
V	2014	Acadia	Body	Frontview Camera Module																																																															
V	2014	Acadia	Body	Theft Deterrent Module																																																															
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																															
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																															
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																																															
V	2015	Acadia	Chassis	Electronic Brake Control Module																																																															
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																																															
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																														
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																														
V	2015	Acadia	Body	Passenger Presence Module																																																															
V	2015	Acadia	Body	Instrument Cluster																																																															
V	2015	Acadia	Body	Head-Up Display Module																																																															
V	2015	Acadia	Body	Radio																																																															
V	2015	Acadia	Body	Rear Audio Control Module																																																															
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																																															
V	2015	Acadia	Body	Personal Audio Link Control Module																																																															
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																																															
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																																															
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																											
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																																												
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																																												
V	2015	Acadia	Body	Liftgate Control Module																																																												
V	2015	Acadia	Body	Seat Memory Control Module																																																												
V	2015	Acadia	Body	Front Seat Heating Control Module																																																												
V	2015	Acadia	Body	Right Side Object Detection Control Module																																																												
V	2015	Acadia	Body	Left Side Object Detection Control Module																																																												
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																																												
V	2015	Acadia	Body	Parking Assist Control Module																																																												
V	2015	Acadia	Body	Frontview Camera Module																																																												
V	2015	Acadia	Body	Theft Deterrent Module																																																												
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																																												
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																																												
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																																												
V	2016	Acadia	Chassis	Electronic Brake Control Module																																																												
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																																												
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																																												
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
V	2016	Acadia	Body	Passenger Presence Module																																																												
V	2016	Acadia	Body	Instrument Cluster																																																												
V	2016	Acadia	Body	Head-Up Display Module																																																												
V	2016	Acadia	Body	Radio																																																											
V	2016	Acadia	Body	Rear Audio Control Module																																																												
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																																												
V	2016	Acadia	Body	Personal Audio Link Control Module																																																												
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																																												
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																																												
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																																												
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																																												
V	2016	Acadia	Body	Liftgate Control Module																																																												
V	2016	Acadia	Body	Seat Memory Control Module																																																												
V	2016	Acadia	Body	Front Seat Heating Control Module																																																												
V	2016	Acadia	Body	Right Side Object Detection Control Module																																																												
V	2016	Acadia	Body	Left Side Object Detection Control Module																																																												
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																																												
V	2016	Acadia	Body	Parking Assist Control Module																																																												
V	2016	Acadia	Body	Frontview Camera Module																																																												
V	2016	Acadia	Body	Theft Deterrent Module																																																												
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																												
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																												
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																												
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																															
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																															
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																															
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																															
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																		
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																													
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																															
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																															
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																			
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module															V	V	V																																													
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																															
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																															
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																															
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																															
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																															
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																															
1	2011	Sierra	Chassis	Electronic Suspension Control																																																															
1	2011	Sierra	Chassis	Trailer Brake Control Module																																																															
1	2011	Sierra	Body	Amplifier (Bose)																																																															
1	2011	Sierra	Body	Body Control Module																																																															
1	2011	Sierra	Body	Body Control Module (aux.)																																																															
1	2011	Sierra	Body	Digital Radio Receiver																																																															
1	2011	Sierra	Body	Driver Door Switch																																																															
1	2011	Sierra	Body	HVAC Control Module Auto																																																															
1	2011	Sierra	Body	HVAC Control Module Manual																																																															
1	2011	Sierra	Body	Instrument Panel Cluster																																																															
1	2011	Sierra	Body	Memory Seat Module																																																															
1	2011	Sierra	Body	Park Assist Module																																																															
1	2011	Sierra	Body	Passenger Door Switch																																																															
1	2011	Sierra	Body	Passenger Presence System																																																															
1	2011	Sierra	Body	Radio																																																															
1	2011	Sierra	Body	Rear Heated Seat Module																																																															
1	2011	Sierra	Body	Rear HVAC/RSA																																																															
1	2011	Sierra	Body	Supplemental Inflatable Restraint																																																															
1	2011	Sierra	Body	Theft Deterrent Module																																																															
1	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																															
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																															
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																															
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																															
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																													
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																															
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																															
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																															
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module			V																																																											
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																															
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																															
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module				V																																																										
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																															
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																															
1	2011	Sierra Hybrid	Body	Body Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																												
1	2011	Sierra Hybrid	Body	Driver Door Switch																																																												
1	2011	Sierra Hybrid	Body	Heated Seat Module																																																												
1	2011	Sierra Hybrid	Body	HVAC Control Module																																																												
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
1	2011	Sierra Hybrid	Body	Park Assist Module																																																												
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																																												
1	2011	Sierra Hybrid	Body	Passenger Presence System																																																												
1	2011	Sierra Hybrid	Body	Radio																																																												
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																												
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
1	2011	Yukon	Chassis	Electronic Brake Control Module																																																												
1	2011	Yukon	Chassis	Electronic Suspension Control																																																												
1	2011	Yukon	Chassis	Trailer Brake Control Module																																																												
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
1	2011	Yukon	Body	Amplifier (Bose)																																																												
1	2011	Yukon	Body	Assist Step Controller																																																												
1	2011	Yukon	Body	Body Control Module																																																												
1	2011	Yukon	Body	Body Control Module (aux.)																																																												
1	2011	Yukon	Body	Digital Radio Receiver																																																												
1	2011	Yukon	Body	Driver Door Switch																																																												
1	2011	Yukon	Body	HVAC Control Module Auto																																																												
1	2011	Yukon	Body	HVAC Control Module Manual																																																												
1	2011	Yukon	Body	Instrument Panel Cluster																																																												
1	2011	Yukon	Body	Left Side Object Detection Module																																																												
1	2011	Yukon	Body	Lift Gate Module																																																												
1	2011	Yukon	Body	Memory Seat Module																																																												
1	2011	Yukon	Body	Park Assist Module																																																												
1	2011	Yukon	Body	Passenger Door Switch																																																												
1	2011	Yukon	Body	Passenger Presence System																																																												
1	2011	Yukon	Body	Radio																																																												
1	2011	Yukon	Body	Rear Heated Seat Module																																																												
1	2011	Yukon	Body	Rear HVAC/RSA																																																												
1	2011	Yukon	Body	Right Side Object Detection Module																																																												
1	2011	Yukon	Body	Supplemental Inflatable Restraint																																																												
1	2011	Yukon	Body	Theft Deterrent Module																																																												
1	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																												
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																												
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module			V																																																							
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module				V																																																						
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																										
1	2011	Yukon Hybrid	Body	Assist Step Controller																																																										
1	2011	Yukon Hybrid	Body	Body Control Module																																																										
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																										
1	2011	Yukon Hybrid	Body	Driver Door Switch																																																										
1	2011	Yukon Hybrid	Body	Heated Seat Module																																																										
1	2011	Yukon Hybrid	Body	HVAC Control Module																																																										
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
1	2011	Yukon Hybrid	Body	Lift Gate Module																																																										
1	2011	Yukon Hybrid	Body	Park Assist Module																																																										
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																																										
1	2011	Yukon Hybrid	Body	Passenger Presence System																																																										
1	2011	Yukon Hybrid	Body	Radio																																																										
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																																										
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																										
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
1	2011	Yukon XL	Body	Amplifier (Bose)																																																										
1	2011	Yukon XL	Body	Assist Step Controller																																																										
1	2011	Yukon XL	Body	Body Control Module																																																										
1	2011	Yukon XL	Body	Body Control Module (aux.)																																																										
1	2011	Yukon XL	Body	Digital Radio Receiver																																																										
1	2011	Yukon XL	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2011	Yukon XL	Body	HVAC Control Module Auto																																																												
1	2011	Yukon XL	Body	HVAC Control Module Manual																																																												
1	2011	Yukon XL	Body	Instrument Panel Cluster																																																												
1	2011	Yukon XL	Body	Left Side Object Detection Module																																																												
1	2011	Yukon XL	Body	Lift Gate Module																																																												
1	2011	Yukon XL	Body	Memory Seat Module																																																												
1	2011	Yukon XL	Body	Park Assist Module																																																												
1	2011	Yukon XL	Body	Passenger Door Switch																																																												
1	2011	Yukon XL	Body	Passenger Presence System																																																												
1	2011	Yukon XL	Body	Radio																																																												
1	2011	Yukon XL	Body	Rear Heated Seat Module																																																												
1	2011	Yukon XL	Body	Rear HVAC/RSA																																																												
1	2011	Yukon XL	Body	Right Side Object Detection Module																																																												
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
1	2011	Yukon XL	Body	Theft Deterrent Module																																																												
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																												
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																												
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																															
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																										
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																												
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V	V	V	V	V	V	V	V																																															
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module															V	V	V																																										
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																												
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																												
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																												
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																												
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																												
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																												
1	2012	Sierra	Chassis	Electronic Suspension Control																																																												
1	2012	Sierra	Chassis	Trailer Brake Control Module																																																												
1	2012	Sierra	Body	Amplifier (Bose)																																																												
1	2012	Sierra	Body	Body Control Module																																																												
1	2012	Sierra	Body	Body Control Module (aux.)																																																												
1	2012	Sierra	Body	Digital Radio Receiver																																																												
1	2012	Sierra	Body	Driver Door Switch																																																												
1	2012	Sierra	Body	HVAC Control Module Auto																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2012	Sierra	Body	HVAC Control Module Manual																																																											
1	2012	Sierra	Body	Instrument Panel Cluster																																																												
1	2012	Sierra	Body	Memory Seat Module																																																												
1	2012	Sierra	Body	Park Assist Module																																																												
1	2012	Sierra	Body	Passenger Door Switch																																																												
1	2012	Sierra	Body	Passenger Presence System																																																												
1	2012	Sierra	Body	Radio																																																												
1	2012	Sierra	Body	Navigation Radio																																																												
1	2012	Sierra	Body	Rear Heated Seat Module																																																												
1	2012	Sierra	Body	Rear HVAC/RSA																																																												
1	2012	Sierra	Body	Supplemental Inflatable Restraint																																																												
1	2012	Sierra	Body	Theft Deterrent Module																																																												
1	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																												
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																												
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																												
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																										
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module			V																																																								
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module				V																																																							
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																												
1	2012	Sierra Hybrid	Body	Body Control Module																																																												
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																												
1	2012	Sierra Hybrid	Body	Driver Door Switch																																																												
1	2012	Sierra Hybrid	Body	Heated Seat Module																																																												
1	2012	Sierra Hybrid	Body	HVAC Control Module																																																												
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
1	2012	Sierra Hybrid	Body	Park Assist Module																																																												
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																																												
1	2012	Sierra Hybrid	Body	Passenger Presence System																																																												
1	2012	Sierra Hybrid	Body	Radio																																																												
1	2012	Sierra Hybrid	Body	Navigation Radio																																																												
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																												
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
1	2012	Yukon	Chassis	Electronic Brake Control Module																																																												
1	2012	Yukon	Chassis	Electronic Suspension Control																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2012	Yukon	Chassis	Trailer Brake Control Module																																																											
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon	Body	Amplifier (Bose)																																																											
1	2012	Yukon	Body	Assist Step Controller																																																											
1	2012	Yukon	Body	Body Control Module																																																											
1	2012	Yukon	Body	Body Control Module (aux.)																																																											
1	2012	Yukon	Body	Digital Radio Receiver																																																											
1	2012	Yukon	Body	Driver Door Switch																																																											
1	2012	Yukon	Body	HVAC Control Module Auto																																																											
1	2012	Yukon	Body	HVAC Control Module Manual																																																											
1	2012	Yukon	Body	Instrument Panel Cluster																																																											
1	2012	Yukon	Body	Left Side Object Detection Module																																																											
1	2012	Yukon	Body	Lift Gate Module																																																											
1	2012	Yukon	Body	Memory Seat Module																																																											
1	2012	Yukon	Body	Park Assist Module																																																											
1	2012	Yukon	Body	Passenger Door Switch																																																											
1	2012	Yukon	Body	Passenger Presence System																																																											
1	2012	Yukon	Body	Radio																																																											
1	2012	Yukon	Body	Navigation Radio																																																											
1	2012	Yukon	Body	Rear Heated Seat Module																																																											
1	2012	Yukon	Body	Rear HVAC/RSA																																																											
1	2012	Yukon	Body	Right Side Object Detection Module																																																											
1	2012	Yukon	Body	Supplemental Inflatable Restraint																																																											
1	2012	Yukon	Body	Theft Deterrent Module																																																											
1	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																											
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																											
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																									
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																											
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																											
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																											
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module			V																																																								
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																											
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																											
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module				V																																																							
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																											
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																											
1	2012	Yukon Hybrid	Body	Assist Step Controller																																																											
1	2012	Yukon Hybrid	Body	Body Control Module																																																											
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																											
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																											
1	2012	Yukon Hybrid	Body	Driver Door Switch																																																											
1	2012	Yukon Hybrid	Body	Heated Seat Module																																																											
1	2012	Yukon Hybrid	Body	HVAC Control Module																																																											
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																											
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																											
1	2012	Yukon Hybrid	Body	Lift Gate Module																																																											
1	2012	Yukon Hybrid	Body	Park Assist Module																																																											
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																																											
1	2012	Yukon Hybrid	Body	Passenger Presence System																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2012	Yukon Hybrid	Body	Radio																																																												
1	2012	Yukon Hybrid	Body	Navigation Radio																																																												
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																												
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																																												
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																												
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
1	2012	Yukon XL	Body	Amplifier (Bose)																																																												
1	2012	Yukon XL	Body	Assist Step Controller																																																												
1	2012	Yukon XL	Body	Body Control Module																																																												
1	2012	Yukon XL	Body	Body Control Module (aux.)																																																												
1	2012	Yukon XL	Body	Digital Radio Receiver																																																												
1	2012	Yukon XL	Body	Driver Door Switch																																																												
1	2012	Yukon XL	Body	HVAC Control Module Auto																																																												
1	2012	Yukon XL	Body	HVAC Control Module Manual																																																												
1	2012	Yukon XL	Body	Instrument Panel Cluster																																																												
1	2012	Yukon XL	Body	Left Side Object Detection Module																																																												
1	2012	Yukon XL	Body	Lift Gate Module																																																												
1	2012	Yukon XL	Body	Memory Seat Module																																																												
1	2012	Yukon XL	Body	Park Assist Module																																																												
1	2012	Yukon XL	Body	Passenger Door Switch																																																												
1	2012	Yukon XL	Body	Passenger Presence System																																																												
1	2012	Yukon XL	Body	Radio																																																												
1	2012	Yukon XL	Body	Navigation Radio																																																												
1	2012	Yukon XL	Body	Rear Heated Seat Module																																																												
1	2012	Yukon XL	Body	Rear HVAC/RSA																																																												
1	2012	Yukon XL	Body	Right Side Object Detection Module																																																												
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
1	2012	Yukon XL	Body	Theft Deterrent Module																																																												
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																												
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																										
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																										
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V	V	V					V							V																																					
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module															V	V	V																																									
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																										
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																										
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																										
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																										
1	2013	Sierra	Chassis	Electronic Suspension Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra	Body	Amplifier (Bose)																																																										
1	2013	Sierra	Body	Body Control Module																																																										
1	2013	Sierra	Body	Body Control Module (aux.)																																																										
1	2013	Sierra	Body	Digital Radio Receiver																																																										
1	2013	Sierra	Body	Driver Door Switch																																																										
1	2013	Sierra	Body	HVAC Control Module Auto																																																										
1	2013	Sierra	Body	HVAC Control Module Manual																																																										
1	2013	Sierra	Body	Instrument Panel Cluster																																																										
1	2013	Sierra	Body	Memory Seat Module																																																										
1	2013	Sierra	Body	Park Assist Module																																																										
1	2013	Sierra	Body	Passenger Door Switch																																																										
1	2013	Sierra	Body	Passenger Presence System																																																										
1	2013	Sierra	Body	Radio																																																										
1	2013	Sierra	Body	Navigation Radio																																																										
1	2013	Sierra	Body	Rear Heated Seat Module																																																										
1	2013	Sierra	Body	Rear HVAC/RSA																																																										
1	2013	Sierra	Body	Supplemental Inflatable Restraint																																																										
1	2013	Sierra	Body	Theft Deterrent Module																																																										
1	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																								
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module			V																																																							
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module				V																																																						
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																										
1	2013	Sierra Hybrid	Body	Body Control Module																																																										
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																										
1	2013	Sierra Hybrid	Body	Driver Door Switch																																																										
1	2013	Sierra Hybrid	Body	Heated Seat Module																																																										
1	2013	Sierra Hybrid	Body	HVAC Control Module																																																										
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
1	2013	Sierra Hybrid	Body	Park Assist Module																																																										
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																																										
1	2013	Sierra Hybrid	Body	Passenger Presence System																																																										
1	2013	Sierra Hybrid	Body	Radio																																																										
1	2013	Sierra Hybrid	Body	Navigation Radio																																																										
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																										
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																										
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																										
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																										
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
1	2013	Yukon	Chassis	Electronic Brake Control Module																																																										
1	2013	Yukon	Chassis	Electronic Suspension Control																																																										
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
1	2013	Yukon	Body	Amplifier (Bose)																																																										
1	2013	Yukon	Body	Assist Step Controller																																																										
1	2013	Yukon	Body	Body Control Module																																																										
1	2013	Yukon	Body	Body Control Module (aux.)																																																										
1	2013	Yukon	Body	Digital Radio Receiver																																																										
1	2013	Yukon	Body	Driver Door Switch																																																										
1	2013	Yukon	Body	HVAC Control Module Auto																																																										
1	2013	Yukon	Body	HVAC Control Module Manual																																																										
1	2013	Yukon	Body	Instrument Panel Cluster																																																										
1	2013	Yukon	Body	Left Side Object Detection Module																																																										
1	2013	Yukon	Body	Lift Gate Module																																																										
1	2013	Yukon	Body	Memory Seat Module																																																										
1	2013	Yukon	Body	Park Assist Module																																																										
1	2013	Yukon	Body	Passenger Door Switch																																																										
1	2013	Yukon	Body	Passenger Presence System																																																										
1	2013	Yukon	Body	Radio																																																										
1	2013	Yukon	Body	Navigation Radio																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2013	Yukon	Body	Rear Heated Seat Module																																																											
1	2013	Yukon	Body	Rear HVAC/RSA																																																												
1	2013	Yukon	Body	Right Side Object Detection Module																																																												
1	2013	Yukon	Body	Supplemental Inflatable Restraint																																																												
1	2013	Yukon	Body	Theft Deterrent Module																																																												
1	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																												
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																												
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																										
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																												
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																												
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																												
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module			V																																																									
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module				V																																																								
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																												
1	2013	Yukon Hybrid	Body	Assist Step Controller																																																												
1	2013	Yukon Hybrid	Body	Body Control Module																																																												
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																												
1	2013	Yukon Hybrid	Body	Driver Door Switch																																																												
1	2013	Yukon Hybrid	Body	Heated Seat Module																																																												
1	2013	Yukon Hybrid	Body	HVAC Control Module																																																												
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
1	2013	Yukon Hybrid	Body	Lift Gate Module																																																												
1	2013	Yukon Hybrid	Body	Park Assist Module																																																												
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																																												
1	2013	Yukon Hybrid	Body	Passenger Presence System																																																												
1	2013	Yukon Hybrid	Body	Radio																																																												
1	2013	Yukon Hybrid	Body	Navigation Radio																																																												
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																												
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																											
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																																												
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
1	2013	Yukon XL	Body	Amplifier (Bose)																																																												
1	2013	Yukon XL	Body	Assist Step Controller																																																												
1	2013	Yukon XL	Body	Body Control Module																																																												
1	2013	Yukon XL	Body	Body Control Module (aux.)																																																												
1	2013	Yukon XL	Body	Digital Radio Receiver																																																												
1	2013	Yukon XL	Body	Driver Door Switch																																																												
1	2013	Yukon XL	Body	HVAC Control Module Auto																																																												
1	2013	Yukon XL	Body	HVAC Control Module Manual																																																												
1	2013	Yukon XL	Body	Instrument Panel Cluster																																																												
1	2013	Yukon XL	Body	Left Side Object Detection Module																																																												
1	2013	Yukon XL	Body	Lift Gate Module																																																												
1	2013	Yukon XL	Body	Memory Seat Module																																																												
1	2013	Yukon XL	Body	Park Assist Module																																																												
1	2013	Yukon XL	Body	Passenger Door Switch																																																												
1	2013	Yukon XL	Body	Passenger Presence System																																																												
1	2013	Yukon XL	Body	Radio																																																												
1	2013	Yukon XL	Body	Navigation Radio																																																												
1	2013	Yukon XL	Body	Rear Heated Seat Module																																																												
1	2013	Yukon XL	Body	Rear HVAC/RSA																																																												
1	2013	Yukon XL	Body	Right Side Object Detection Module																																																												
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																												
1	2013	Yukon XL	Body	Theft Deterrent Module																																																												
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																												
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																												
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2014	Sierra	Chassis	Electronic Brake Control Module																																																												
1	2014	Sierra	Chassis	Parking Brake Control Module																																																												
1	2014	Sierra	Chassis	Power Steering Control Module																																																												
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2014	Sierra	Body	Body Control Module																																																												
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	Sierra	Body	Passenger Presence Module																																																												
1	2014	Sierra	Body	Instrument Cluster																																																												
1	2014	Sierra	Body	Radio Control																																																												
1	2014	Sierra	Body	HVAC Control																																																												
1	2014	Sierra	Body	Radio																																																												
1	2014	Sierra	Body	Amplifier																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2014	Sierra	Body	Media Disc Player																																																										
1	2014	Sierra	Body	Human Machine Interface Control Module																																																										
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2014	Sierra	Body	Parking Assist Control Module																																																										
1	2014	Sierra	Body	Frontview Camera Module																																																										
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																							V																																			
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																							V																																			
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module							V																	V	V	V	V	V	V	V	V																											
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																								V																																		
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																										
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																										
1	2014	Sierra HD	Chassis	Suspension Control Module																																																										
1	2014	Sierra HD	Body	Body Control Module																																																										
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2014	Sierra HD	Body	Instrument Cluster																																																										
1	2014	Sierra HD	Body	Base Radio																																																										
1	2014	Sierra HD	Body	Navigation Radio																																																										
1	2014	Sierra HD	Body	Uplevel Radio																																																										
1	2014	Sierra HD	Body	Amplifier																																																										
1	2014	Sierra HD	Body	Rear Audio Control Module																																																										
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																										
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																																										
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																										
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																										
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																										
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																										
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																										
1	2014	Sierra HD	Body	Seat Memory Control Module																																																										
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																										
1	2014	Sierra HD	Body	Parking Assist Control Module																																																										
1	2014	Sierra HD	Body	Theft Deterrent Module																																																										
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																										
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																										
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																										
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																										
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																										
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																										
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2014	Yukon	Chassis	Electronic Brake Control Module																																																											
1	2014	Yukon	Chassis	Parking Brake Control Module																																																											
1	2014	Yukon	Chassis	Suspension Control Module																																																											
1	2014	Yukon	Body	Body Control Module																																																											
1	2014	Yukon	Body	Auxiliary Body Control Module																																																											
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2014	Yukon	Body	Passenger Presence Module																																																												
1	2014	Yukon	Body	Instrument Cluster																																																												
1	2014	Yukon	Body	Base Radio																																																												
1	2014	Yukon	Body	Navigation Radio																																																												
1	2014	Yukon	Body	Uplevel Radio																																																												
1	2014	Yukon	Body	Amplifier																																																												
1	2014	Yukon	Body	Rear Audio Control Module																																																												
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																																												
1	2014	Yukon	Body	Personal Audio Link Control Module																																																												
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																												
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																												
1	2014	Yukon	Body	Liftgate Control Module																																																												
1	2014	Yukon	Body	Seat Memory Control Module																																																												
1	2014	Yukon	Body	Rear Seat Heating Control Module																																																												
1	2014	Yukon	Body	Assist Step Control Module																																																												
1	2014	Yukon	Body	Right Side Object Detection Control Module																																																												
1	2014	Yukon	Body	Left Side Object Detection Control Module																																																												
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																																												
1	2014	Yukon	Body	Parking Assist Control Module																																																												
1	2014	Yukon	Body	Theft Deterrent Module																																																												
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																												
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																												
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																												
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																												
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																																												
1	2014	Yukon XL	Chassis	Suspension Control Module																																																												
1	2014	Yukon XL	Body	Body Control Module																																																												
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																																												
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2014	Yukon XL	Body	Passenger Presence Module																																																												
1	2014	Yukon XL	Body	Instrument Cluster																																																												
1	2014	Yukon XL	Body	Base Radio																																																												
1	2014	Yukon XL	Body	Navigation Radio																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2014	Yukon XL	Body	Uplevel Radio																																																											
1	2014	Yukon XL	Body	Amplifier																																																												
1	2014	Yukon XL	Body	Rear Audio Control Module																																																												
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																												
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																																												
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																												
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																												
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																												
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																												
1	2014	Yukon XL	Body	Liftgate Control Module																																																												
1	2014	Yukon XL	Body	Seat Memory Control Module																																																												
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																												
1	2014	Yukon XL	Body	Assist Step Control Module																																																												
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																												
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																												
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																												
1	2014	Yukon XL	Body	Parking Assist Control Module																																																												
1	2014	Yukon XL	Body	Theft Deterrent Module																																																												
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																												
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																							V																																					
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																							V																																					
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module							V																	V	V	V	V	V	V	V	V																													
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																												
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																												
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																								V																																			
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																												
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																												
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2015	Sierra	Chassis	Electronic Brake Control Module																																																												
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																												
1	2015	Sierra	Chassis	Power Steering Control Module																																																												
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2015	Sierra	Chassis	Suspension Control Module																																																												
1	2015	Sierra	Body	Body Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Sierra	Body	Passenger Presence Module																																																											
1	2015	Sierra	Body	Instrument Cluster																																																											
1	2015	Sierra	Body	Radio Controls																																																											
1	2015	Sierra	Body	HVAC Controls																																																											
1	2015	Sierra	Body	Radio																																																											
1	2015	Sierra	Body	Amplifier																																																											
1	2015	Sierra	Body	Media Disc Player																																																											
1	2015	Sierra	Body	Human Machine Interface Control Module																																																											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
1	2015	Sierra	Body	Parking Assist Control Module																																																											
1	2015	Sierra	Body	Frontview Camera Module																																																											
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																											
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																											
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																											
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																											
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																											
1	2015	Yukon	Chassis	Electronic Brake Control Module																																																											
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																											
1	2015	Yukon	Chassis	Parking Brake Control Module																																																											
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																											
1	2015	Yukon	Chassis	Power Steering Control Module																																																											
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2015	Yukon	Chassis	Suspension Control Module																																																											
1	2015	Yukon	Body	Body Control Module																																																											
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2015	Yukon	Body	Passenger Presence Module																																																											
1	2015	Yukon	Body	Instrument Cluster																																																											
1	2015	Yukon	Body	Radio Controls																																																											
1	2015	Yukon	Body	HVAC Controls																																																											
1	2015	Yukon	Body	Radio																																																											
1	2015	Yukon	Body	Amplifier																																																											
1	2015	Yukon	Body	Media Disc Player																																																											
1	2015	Yukon	Body	Human Machine Interface Control Module																																																											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2015	Yukon	Body	HVAC Control Module																																																										
1	2015	Yukon	Body	Liftgate Control Module																																																										
1	2015	Yukon	Body	Keyless Entry Control Module																																																										
1	2015	Yukon	Body	Assist Step Control Module																																																										
1	2015	Yukon	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon	Body	Parking Assist Control Module																																																										
1	2015	Yukon	Body	Frontview Camera Module																																																										
1	2015	Yukon	Body	Steering Column Lock Control Module																																																										
1	2015	Yukon	Body	Battery Energy Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																										
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
1	2015	Yukon XL	Chassis	Power Steering Control Module																																																										
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
1	2015	Yukon XL	Chassis	Suspension Control Module																																																										
1	2015	Yukon XL	Body	Body Control Module																																																										
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
1	2015	Yukon XL	Body	Passenger Presence Module																																																										
1	2015	Yukon XL	Body	Instrument Cluster																																																										
1	2015	Yukon XL	Body	Radio Controls																																																										
1	2015	Yukon XL	Body	HVAC Controls																																																										
1	2015	Yukon XL	Body	Radio																																																										
1	2015	Yukon XL	Body	Amplifier																																																										
1	2015	Yukon XL	Body	Media Disc Player																																																										
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
1	2015	Yukon XL	Body	HVAC Control Module																																																										
1	2015	Yukon XL	Body	Liftgate Control Module																																																										
1	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
1	2015	Yukon XL	Body	Assist Step Control Module																																																										
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
1	2015	Yukon XL	Body	Parking Assist Control Module																																																										
1	2015	Yukon XL	Body	Frontview Camera Module																																																										
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																											
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																											
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																											
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																V	V	V																							
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																											
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																						V																																				
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																						V																																				
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																											
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module							V																	V	V	V	V	V	V	V	V																												
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																											
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																											
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																							V																																				
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																											
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																											
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2016	Sierra	Chassis	Electronic Brake Control Module																																																											
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																											
1	2016	Sierra	Chassis	Parking Brake Control Module																																																											
1	2016	Sierra	Chassis	Power Steering Control Module																																			V	V	V																							
1	2016	Sierra	Chassis	Power Steering Control Module																																																											
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	Sierra	Chassis	Suspension Control Module																																																											
1	2016	Sierra	Body	Body Control Module																																																											
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
1	2016	Sierra	Body	Passenger Presence Module																																																											
1	2016	Sierra	Body	Instrument Cluster																																																											
1	2016	Sierra	Body	Radio Controls																																																											
1	2016	Sierra	Body	HVAC Controls																																																											
1	2016	Sierra	Body	Radio (IO3)																																																											
1	2016	Sierra	Body	Radio (IOB)																																																											
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																											
1	2016	Sierra	Body	Amplifier																																																											
1	2016	Sierra	Body	Media Disc Player																																																											
1	2016	Sierra	Body	Human Machine Interface Control Module																																																											
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																																											
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																																											
1	2016	Sierra	Body	Left Side Object Detection Control Module																																																											
1	2016	Sierra	Body	Parking Assist Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2016	Sierra	Body	Frontview Camera Module																																																											
1	2016	Sierra	Body	Frontview Camera Module																																																												
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
1	2016	Yukon	Chassis	Electronic Brake Control Module																																																												
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																												
1	2016	Yukon	Chassis	Parking Brake Control Module																																																												
1	2016	Yukon	Chassis	Power Steering Control Module																																																												
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																												
1	2016	Yukon	Chassis	Suspension Control Module																																																												
1	2016	Yukon	Body	Body Control Module																																																												
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
1	2016	Yukon	Body	Passenger Presence Module																																																												
1	2016	Yukon	Body	Instrument Cluster																																																												
1	2016	Yukon	Body	Radio Controls																																																											
1	2016	Yukon	Body	HVAC Controls																																																											
1	2016	Yukon	Body	Radio																																																											
1	2016	Yukon	Body	Amplifier																																																											
1	2016	Yukon	Body	Media Disc Player																																																											
1	2016	Yukon	Body	Human Machine Interface Control Module																																																											
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																																											
1	2016	Yukon	Body	HVAC Control Module																																																											
1	2016	Yukon	Body	Liftgate Control Module																																																											
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																											
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																																											
1	2016	Yukon	Body	Keyless Entry Control Module																																																											
1	2016	Yukon	Body	Assist Step Control Module																																																											
1	2016	Yukon	Body	Left Side Object Detection Control Module																																																											
1	2016	Yukon	Body	Parking Assist Control Module																																																											
1	2016	Yukon	Body	Frontview Camera Module																																																											
1	2016	Yukon	Body	Steering Column Lock Control Module																																																											
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																											
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																											
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																																											
1	2016	Yukon XL	Chassis	Power Steering Control Module																																																											
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																											
1	2016	Yukon XL	Chassis	Suspension Control Module																																																											
1	2016	Yukon XL	Body	Body Control Module																																																											
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
1	2016	Yukon XL	Body	Passenger Presence Module																																																														
1	2016	Yukon XL	Body	Instrument Cluster																																																														
1	2016	Yukon XL	Body	Radio Controls																																																														
1	2016	Yukon XL	Body	HVAC Controls																																																														
1	2016	Yukon XL	Body	Radio																																																														
1	2016	Yukon XL	Body	Amplifier																																																														
1	2016	Yukon XL	Body	Media Disc Player																																																														
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																																														
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																														
1	2016	Yukon XL	Body	HVAC Control Module																																																														
1	2016	Yukon XL	Body	Liftgate Control Module																																																														
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																														
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																														
1	2016	Yukon XL	Body	Keyless Entry Control Module																																																														
1	2016	Yukon XL	Body	Assist Step Control Module																																																														
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																														
1	2016	Yukon XL	Body	Parking Assist Control Module																																																														
1	2016	Yukon XL	Body	Frontview Camera Module																																																														
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																																														
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																														
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																														
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																														
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																														
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																														
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																														
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																																														
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																														
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																														
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																														
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																														
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																														
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																														
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																														
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																														
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																														
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																	
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																												
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																														
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																														
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																														
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																	
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module															V	V	V																																												
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																														
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																														
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																										
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																										
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																										
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																										
2	2011	Sierra	Chassis	Electronic Suspension Control																																																										
2	2011	Sierra	Chassis	Trailer Brake Control Module																																																										
2	2011	Sierra	Body	Amplifier (Bose)																																																										
2	2011	Sierra	Body	Body Control Module																																																										
2	2011	Sierra	Body	Body Control Module (aux.)																																																										
2	2011	Sierra	Body	Digital Radio Receiver																																																										
2	2011	Sierra	Body	Driver Door Switch																																																										
2	2011	Sierra	Body	HVAC Control Module Auto																																																										
2	2011	Sierra	Body	HVAC Control Module Manual																																																										
2	2011	Sierra	Body	Instrument Panel Cluster																																																										
2	2011	Sierra	Body	Memory Seat Module																																																										
2	2011	Sierra	Body	Park Assist Module																																																										
2	2011	Sierra	Body	Passenger Door Switch																																																										
2	2011	Sierra	Body	Passenger Presence System																																																										
2	2011	Sierra	Body	Radio																																																										
2	2011	Sierra	Body	Rear Heated Seat Module																																																										
2	2011	Sierra	Body	Rear HVAC/RSA																																																										
2	2011	Sierra	Body	Supplemental Inflatable Restraint																																																										
2	2011	Sierra	Body	Theft Deterrent Module																																																										
2	2011	Sierra Hybrid	Powertrain	Engine Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																																										
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																								
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																																										
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module			V																																																							
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																																										
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module				V																																																					
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																																										
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																																										
2	2011	Sierra Hybrid	Body	Body Control Module																																																										
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																																										
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																																										
2	2011	Sierra Hybrid	Body	Driver Door Switch																																																										
2	2011	Sierra Hybrid	Body	Heated Seat Module																																																										
2	2011	Sierra Hybrid	Body	HVAC Control Module																																																										
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																																										
2	2011	Sierra Hybrid	Body	Park Assist Module																																																										
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																																										
2	2011	Sierra Hybrid	Body	Passenger Presence System																																																										
2	2011	Sierra Hybrid	Body	Radio																																																										
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																																										
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																																																
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																																
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																																																																
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																																
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																																
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																																
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																																
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																																
2	2011	Yukon	Chassis	Electronic Brake Control Module																																																																
2	2011	Yukon	Chassis	Electronic Suspension Control																																																																
2	2011	Yukon	Chassis	Trailer Brake Control Module																																																																
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																																																
2	2011	Yukon	Body	Amplifier (Bose)																																																																
2	2011	Yukon	Body	Assist Step Controller																																																																
2	2011	Yukon	Body	Body Control Module																																																																
2	2011	Yukon	Body	Body Control Module (aux.)																																																																
2	2011	Yukon	Body	Digital Radio Receiver																																																																
2	2011	Yukon	Body	Driver Door Switch																																																																
2	2011	Yukon	Body	HVAC Control Module Auto																																																																
2	2011	Yukon	Body	HVAC Control Module Manual																																																																
2	2011	Yukon	Body	Instrument Panel Cluster																																																																
2	2011	Yukon	Body	Left Side Object Detection Module																																																																
2	2011	Yukon	Body	Lift Gate Module																																																																
2	2011	Yukon	Body	Memory Seat Module																																																																
2	2011	Yukon	Body	Park Assist Module																																																																
2	2011	Yukon	Body	Passenger Door Switch																																																																
2	2011	Yukon	Body	Passenger Presence System																																																																
2	2011	Yukon	Body	Radio																																																																
2	2011	Yukon	Body	Rear Heated Seat Module																																																																
2	2011	Yukon	Body	Rear HVAC/RSA																																																																
2	2011	Yukon	Body	Right Side Object Detection Module																																																																
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																																																
2	2011	Yukon	Body	Theft Deterrent Module																																																																
2	2011	Yukon Hybrid	Powertrain	Engine Control Module																																																																
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																																																
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																																
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																																
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																														
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																																
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																																
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																																																
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																																
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module			V																																																												
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																																																
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																																
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module				V																																																											
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																																																
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2011	Yukon Hybrid	Body	Assist Step Controller																																																																
2	2011	Yukon Hybrid	Body	Body Control Module																																																																
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																																																
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																																																
2	2011	Yukon Hybrid	Body	Driver Door Switch																																																																
2	2011	Yukon Hybrid	Body	Heated Seat Module																																																																
2	2011	Yukon Hybrid	Body	HVAC Control Module																																																																
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																																																
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																																																
2	2011	Yukon Hybrid	Body	Lift Gate Module																																																																
2	2011	Yukon Hybrid	Body	Park Assist Module																																																																
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																																																
2	2011	Yukon Hybrid	Body	Passenger Presence System																																																																
2	2011	Yukon Hybrid	Body	Radio																																																																
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																																																
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																																																
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																																																
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																																																
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																																
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																																																																
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																																																
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																																																
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																																																
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																																
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																																
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																																
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																																
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																																
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																																
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																																
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																																
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																																
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																																
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																																
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																																
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																																
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																																																
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																																
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																																																
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																																																
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																																
2	2011	Yukon XL	Body	Amplifier (Bose)																																																																
2	2011	Yukon XL	Body	Assist Step Controller																																																																
2	2011	Yukon XL	Body	Body Control Module																																																																
2	2011	Yukon XL	Body	Body Control Module (aux.)																																																																
2	2011	Yukon XL	Body	Digital Radio Receiver																																																																
2	2011	Yukon XL	Body	Driver Door Switch																																																																
2	2011	Yukon XL	Body	HVAC Control Module Auto																																																																
2	2011	Yukon XL	Body	HVAC Control Module Manual																																																																
2	2011	Yukon XL	Body	Instrument Panel Cluster																																																																
2	2011	Yukon XL	Body	Left Side Object Detection Module																																																																

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2011	Yukon XL	Body	Lift Gate Module																																																												
2	2011	Yukon XL	Body	Memory Seat Module																																																													
2	2011	Yukon XL	Body	Park Assist Module																																																													
2	2011	Yukon XL	Body	Passenger Door Switch																																																													
2	2011	Yukon XL	Body	Passenger Presence System																																																													
2	2011	Yukon XL	Body	Radio																																																													
2	2011	Yukon XL	Body	Rear Heated Seat Module																																																													
2	2011	Yukon XL	Body	Rear HVAC/RSA																																																													
2	2011	Yukon XL	Body	Right Side Object Detection Module																																																													
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																																													
2	2011	Yukon XL	Body	Theft Deterrent Module																																																													
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																													
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																													
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																													
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																													
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																													
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																													
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																													
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																													
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																													
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																											
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																																													
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																													
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																																													
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module															V	V	V																																											
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																													
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																													
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																													
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																													
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																																													
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																																													
2	2012	Sierra	Chassis	Electronic Suspension Control																																																													
2	2012	Sierra	Chassis	Trailer Brake Control Module																																																													
2	2012	Sierra	Body	Amplifier (Bose)																																																													
2	2012	Sierra	Body	Body Control Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2012	Sierra	Body	Body Control Module (aux.)																																																											
2	2012	Sierra	Body	Digital Radio Receiver																																																												
2	2012	Sierra	Body	Driver Door Switch																																																												
2	2012	Sierra	Body	HVAC Control Module Auto																																																												
2	2012	Sierra	Body	HVAC Control Module Manual																																																												
2	2012	Sierra	Body	Instrument Panel Cluster																																																												
2	2012	Sierra	Body	Memory Seat Module																																																												
2	2012	Sierra	Body	Park Assist Module																																																												
2	2012	Sierra	Body	Passenger Door Switch																																																												
2	2012	Sierra	Body	Passenger Presence System																																																												
2	2012	Sierra	Body	Radio																																																												
2	2012	Sierra	Body	Navigation Radio																																																												
2	2012	Sierra	Body	Rear Heated Seat Module																																																												
2	2012	Sierra	Body	Rear HVAC/RSA																																																												
2	2012	Sierra	Body	Supplemental Inflatable Restraint																																																												
2	2012	Sierra	Body	Theft Deterrent Module																																																												
2	2012	Sierra Hybrid	Powertrain	Engine Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																																												
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																										
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																												
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module			V																																																									
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module				V																																																							
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																																												
2	2012	Sierra Hybrid	Body	Body Control Module																																																												
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																																												
2	2012	Sierra Hybrid	Body	Driver Door Switch																																																												
2	2012	Sierra Hybrid	Body	Heated Seat Module																																																												
2	2012	Sierra Hybrid	Body	HVAC Control Module																																																												
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
2	2012	Sierra Hybrid	Body	Park Assist Module																																																												
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																																												
2	2012	Sierra Hybrid	Body	Passenger Presence System																																																												
2	2012	Sierra Hybrid	Body	Radio																																																												
2	2012	Sierra Hybrid	Body	Navigation Radio																																																												
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																																																												
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																										
2	2012	Yukon	Chassis	Electronic Brake Control Module																																																										
2	2012	Yukon	Chassis	Electronic Suspension Control																																																										
2	2012	Yukon	Chassis	Trailer Brake Control Module																																																										
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Yukon	Body	Amplifier (Bose)																																																										
2	2012	Yukon	Body	Assist Step Controller																																																										
2	2012	Yukon	Body	Body Control Module																																																										
2	2012	Yukon	Body	Body Control Module (aux.)																																																										
2	2012	Yukon	Body	Digital Radio Receiver																																																										
2	2012	Yukon	Body	Driver Door Switch																																																										
2	2012	Yukon	Body	HVAC Control Module Auto																																																										
2	2012	Yukon	Body	HVAC Control Module Manual																																																										
2	2012	Yukon	Body	Instrument Panel Cluster																																																										
2	2012	Yukon	Body	Left Side Object Detection Module																																																										
2	2012	Yukon	Body	Lift Gate Module																																																										
2	2012	Yukon	Body	Memory Seat Module																																																										
2	2012	Yukon	Body	Park Assist Module																																																										
2	2012	Yukon	Body	Passenger Door Switch																																																										
2	2012	Yukon	Body	Passenger Presence System																																																										
2	2012	Yukon	Body	Radio																																																										
2	2012	Yukon	Body	Navigation Radio																																																										
2	2012	Yukon	Body	Rear Heated Seat Module																																																										
2	2012	Yukon	Body	Rear HVAC/RSA																																																										
2	2012	Yukon	Body	Right Side Object Detection Module																																																										
2	2012	Yukon	Body	Supplemental Inflatable Restraint																																																										
2	2012	Yukon	Body	Theft Deterrent Module																																																										
2	2012	Yukon Hybrid	Powertrain	Engine Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																																										
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																								
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																										
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																										
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																																										
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																										
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module			V																																																							
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																																										
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																										
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module				V																																																					
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																																										
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																																										
2	2012	Yukon Hybrid	Body	Assist Step Controller																																																										
2	2012	Yukon Hybrid	Body	Body Control Module																																																										
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																																										
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																																										
2	2012	Yukon Hybrid	Body	Driver Door Switch																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2012	Yukon Hybrid	Body	Heated Seat Module																																																												
2	2012	Yukon Hybrid	Body	HVAC Control Module																																																												
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																																												
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																																												
2	2012	Yukon Hybrid	Body	Lift Gate Module																																																												
2	2012	Yukon Hybrid	Body	Park Assist Module																																																												
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																																												
2	2012	Yukon Hybrid	Body	Passenger Presence System																																																												
2	2012	Yukon Hybrid	Body	Radio																																																												
2	2012	Yukon Hybrid	Body	Navigation Radio																																																												
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																																												
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																																												
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																																												
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																																												
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																												
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																																																												
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																												
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																												
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																												
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																												
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																												
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																												
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																												
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																												
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																																												
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																												
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																																												
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																																												
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																												
2	2012	Yukon XL	Body	Amplifier (Bose)																																																												
2	2012	Yukon XL	Body	Assist Step Controller																																																												
2	2012	Yukon XL	Body	Body Control Module																																																												
2	2012	Yukon XL	Body	Body Control Module (aux.)																																																												
2	2012	Yukon XL	Body	Digital Radio Receiver																																																												
2	2012	Yukon XL	Body	Driver Door Switch																																																												
2	2012	Yukon XL	Body	HVAC Control Module Auto																																																												
2	2012	Yukon XL	Body	HVAC Control Module Manual																																																												
2	2012	Yukon XL	Body	Instrument Panel Cluster																																																												
2	2012	Yukon XL	Body	Left Side Object Detection Module																																																												
2	2012	Yukon XL	Body	Lift Gate Module																																																												
2	2012	Yukon XL	Body	Memory Seat Module																																																												
2	2012	Yukon XL	Body	Park Assist Module																																																												
2	2012	Yukon XL	Body	Passenger Door Switch																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2012	Yukon XL	Body	Passenger Presence System																																																												
2	2012	Yukon XL	Body	Radio																																																													
2	2012	Yukon XL	Body	Navigation Radio																																																													
2	2012	Yukon XL	Body	Rear Heated Seat Module																																																													
2	2012	Yukon XL	Body	Rear HVAC/RSA																																																													
2	2012	Yukon XL	Body	Right Side Object Detection Module																																																													
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																																													
2	2012	Yukon XL	Body	Theft Deterrent Module																																																													
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																													
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																													
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																																													
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																													
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																																													
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																													
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																																													
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																													
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																													
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																													
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																																													
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																													
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																													
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																													
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																																													
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																													
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																													
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																													
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																													
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																																													
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																													
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																																													
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																																													
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																																													
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																																													
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																																													
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module							V	V	V					V							V																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module															V	V	V																																											
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																																													
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																																													
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																																													
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																																													
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																																													
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																																													
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																																													
2	2013	Sierra	Chassis	Electronic Suspension Control																																																													
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																													
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																																													
2	2013	Sierra	Body	Amplifier (Bose)																																																													
2	2013	Sierra	Body	Body Control Module																																																													
2	2013	Sierra	Body	Body Control Module (aux.)																																																													
2	2013	Sierra	Body	Digital Radio Receiver																																																													
2	2013	Sierra	Body	Driver Door Switch																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2013	Sierra	Body	HVAC Control Module Auto																																																											
2	2013	Sierra	Body	HVAC Control Module Manual																																																												
2	2013	Sierra	Body	Instrument Panel Cluster																																																												
2	2013	Sierra	Body	Memory Seat Module																																																												
2	2013	Sierra	Body	Park Assist Module																																																												
2	2013	Sierra	Body	Passenger Door Switch																																																												
2	2013	Sierra	Body	Passenger Presence System																																																												
2	2013	Sierra	Body	Radio																																																												
2	2013	Sierra	Body	Navigation Radio																																																												
2	2013	Sierra	Body	Rear Heated Seat Module																																																												
2	2013	Sierra	Body	Rear HVAC/RSA																																																												
2	2013	Sierra	Body	Supplemental Inflatable Restraint																																																												
2	2013	Sierra	Body	Theft Deterrent Module																																																												
2	2013	Sierra Hybrid	Powertrain	Engine Control Module																																																												
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																																												
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																																												
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																																												
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																										
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																																												
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																																												
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																																												
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																																												
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module			V																																																								
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																																												
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module				V																																																							
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																																												
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																																												
2	2013	Sierra Hybrid	Body	Body Control Module																																																												
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																																												
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																																												
2	2013	Sierra Hybrid	Body	Driver Door Switch																																																												
2	2013	Sierra Hybrid	Body	Heated Seat Module																																																												
2	2013	Sierra Hybrid	Body	HVAC Control Module																																																												
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																																												
2	2013	Sierra Hybrid	Body	Park Assist Module																																																												
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																																												
2	2013	Sierra Hybrid	Body	Passenger Presence System																																																												
2	2013	Sierra Hybrid	Body	Radio																																																												
2	2013	Sierra Hybrid	Body	Navigation Radio																																																												
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																																												
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																																												
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																																												
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																																												
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																																																												
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																												
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																												
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																												
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																												
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																												
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																												
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																																												
2	2013	Yukon	Chassis	Electronic Brake Control Module																																																												
2	2013	Yukon	Chassis	Electronic Suspension Control																																																												
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																																												
2	2013	Yukon	Body	Amplifier (Bose)																																																												
2	2013	Yukon	Body	Assist Step Controller																																																												
2	2013	Yukon	Body	Body Control Module																																																												
2	2013	Yukon	Body	Body Control Module (aux.)																																																												
2	2013	Yukon	Body	Digital Radio Receiver																																																												
2	2013	Yukon	Body	Driver Door Switch																																																												
2	2013	Yukon	Body	HVAC Control Module Auto																																																												
2	2013	Yukon	Body	HVAC Control Module Manual																																																												
2	2013	Yukon	Body	Instrument Panel Cluster																																																												
2	2013	Yukon	Body	Left Side Object Detection Module																																																												
2	2013	Yukon	Body	Lift Gate Module																																																												
2	2013	Yukon	Body	Memory Seat Module																																																												
2	2013	Yukon	Body	Park Assist Module																																																												
2	2013	Yukon	Body	Passenger Door Switch																																																												
2	2013	Yukon	Body	Passenger Presence System																																																												
2	2013	Yukon	Body	Radio																																																												
2	2013	Yukon	Body	Navigation Radio																																																												
2	2013	Yukon	Body	Rear Heated Seat Module																																																												
2	2013	Yukon	Body	Rear HVAC/RSA																																																												
2	2013	Yukon	Body	Right Side Object Detection Module																																																												
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																																												
2	2013	Yukon	Body	Theft Deterrent Module																																																												
2	2013	Yukon Hybrid	Powertrain	Engine Control Module																																																												
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																																												
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																																												
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																																												
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module	V	V																																																										
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																																												
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																																												
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																																												
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																																												
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module			V																																																								
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																																												
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																																												
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module				V																																																							
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																																												
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																																												
2	2013	Yukon Hybrid	Body	Assist Step Controller																																																												
2	2013	Yukon Hybrid	Body	Body Control Module																																																												
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																																												
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																																												
2	2013	Yukon Hybrid	Body	Driver Door Switch																																																												
2	2013	Yukon Hybrid	Body	Heated Seat Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2013	Yukon Hybrid	Body	HVAC Control Module																																																										
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																																										
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																																										
2	2013	Yukon Hybrid	Body	Lift Gate Module																																																										
2	2013	Yukon Hybrid	Body	Park Assist Module																																																										
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																																										
2	2013	Yukon Hybrid	Body	Passenger Presence System																																																										
2	2013	Yukon Hybrid	Body	Radio																																																										
2	2013	Yukon Hybrid	Body	Navigation Radio																																																										
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																																										
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																																										
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																																										
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																																										
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																																										
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																																										
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																																										
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																																										
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																																										
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																																										
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																																										
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																																										
2	2013	Yukon XL	Body	Amplifier (Bose)																																																										
2	2013	Yukon XL	Body	Assist Step Controller																																																										
2	2013	Yukon XL	Body	Body Control Module																																																										
2	2013	Yukon XL	Body	Body Control Module (aux.)																																																										
2	2013	Yukon XL	Body	Digital Radio Receiver																																																										
2	2013	Yukon XL	Body	Driver Door Switch																																																										
2	2013	Yukon XL	Body	HVAC Control Module Auto																																																										
2	2013	Yukon XL	Body	HVAC Control Module Manual																																																										
2	2013	Yukon XL	Body	Instrument Panel Cluster																																																										
2	2013	Yukon XL	Body	Left Side Object Detection Module																																																										
2	2013	Yukon XL	Body	Lift Gate Module																																																										
2	2013	Yukon XL	Body	Memory Seat Module																																																										
2	2013	Yukon XL	Body	Park Assist Module																																																										
2	2013	Yukon XL	Body	Passenger Door Switch																																																										
2	2013	Yukon XL	Body	Passenger Presence System																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2013	Yukon XL	Body	Radio																																																										
2	2013	Yukon XL	Body	Navigation Radio																																																										
2	2013	Yukon XL	Body	Rear Heated Seat Module																																																										
2	2013	Yukon XL	Body	Rear HVAC/RSA																																																										
2	2013	Yukon XL	Body	Right Side Object Detection Module																																																										
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																																										
2	2013	Yukon XL	Body	Theft Deterrent Module																																																										
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																										
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																																										
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																										
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																										
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																										
2	2014	Sierra	Chassis	Electronic Brake Control Module																																																										
2	2014	Sierra	Chassis	Parking Brake Control Module																																																										
2	2014	Sierra	Chassis	Power Steering Control Module																																																										
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2014	Sierra	Body	Body Control Module																																																										
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2014	Sierra	Body	Passenger Presence Module																																																										
2	2014	Sierra	Body	Instrument Cluster																																																										
2	2014	Sierra	Body	Radio Control																																																										
2	2014	Sierra	Body	HVAC Control																																																										
2	2014	Sierra	Body	Radio																																																										
2	2014	Sierra	Body	Amplifier																																																										
2	2014	Sierra	Body	Media Disc Player																																																										
2	2014	Sierra	Body	Human Machine Interface Control Module																																																										
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																																										
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																										
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																										
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																										
2	2014	Sierra	Body	Parking Assist Control Module																																																										
2	2014	Sierra	Body	Frontview Camera Module																																																										
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																								V																																		
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																								V																																		
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module						V																			V	V	V	V	V	V	V																											
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																									V																																	
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																																										
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																																										
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																																										
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2014	Sierra HD	Chassis	Suspension Control Module																																																														
2	2014	Sierra HD	Body	Body Control Module																																																															
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
2	2014	Sierra HD	Body	Instrument Cluster																																																															
2	2014	Sierra HD	Body	Base Radio																																																															
2	2014	Sierra HD	Body	Navigation Radio																																																															
2	2014	Sierra HD	Body	Uplevel Radio																																																															
2	2014	Sierra HD	Body	Amplifier																																																															
2	2014	Sierra HD	Body	Rear Audio Control Module																																																															
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																																															
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																																															
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																																															
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																																															
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																																															
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																																															
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																																															
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																																															
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																																															
2	2014	Sierra HD	Body	Seat Memory Control Module																																																															
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																																															
2	2014	Sierra HD	Body	Parking Assist Control Module																																																															
2	2014	Sierra HD	Body	Theft Deterrent Module																																																															
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																																															
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																																															
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																																															
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																																															
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																																															
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																															
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																															
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																															
2	2014	Yukon	Chassis	Electronic Brake Control Module																																																															
2	2014	Yukon	Chassis	Parking Brake Control Module																																																															
2	2014	Yukon	Chassis	Suspension Control Module																																																															
2	2014	Yukon	Body	Body Control Module																																																															
2	2014	Yukon	Body	Auxiliary Body Control Module																																																															
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																															
2	2014	Yukon	Body	Passenger Presence Module																																																															
2	2014	Yukon	Body	Instrument Cluster																																																															
2	2014	Yukon	Body	Base Radio																																																															
2	2014	Yukon	Body	Navigation Radio																																																															
2	2014	Yukon	Body	Uplevel Radio																																																															
2	2014	Yukon	Body	Amplifier																																																															
2	2014	Yukon	Body	Rear Audio Control Module																																																															
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																																															
2	2014	Yukon	Body	Personal Audio Link Control Module																																																															
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																																															
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																															
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																																															
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																																															
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																																											
2	2014	Yukon	Body	Liftgate Control Module																																																												
2	2014	Yukon	Body	Seat Memory Control Module																																																												
2	2014	Yukon	Body	Rear Seat Heating Control Module																																																												
2	2014	Yukon	Body	Assist Step Control Module																																																												
2	2014	Yukon	Body	Right Side Object Detection Control Module																																																												
2	2014	Yukon	Body	Left Side Object Detection Control Module																																																												
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																																												
2	2014	Yukon	Body	Parking Assist Control Module																																																												
2	2014	Yukon	Body	Theft Deterrent Module																																																												
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																																												
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																																												
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																																												
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																																												
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																																												
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																																												
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																																												
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																																												
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																																												
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																																												
2	2014	Yukon XL	Chassis	Suspension Control Module																																																												
2	2014	Yukon XL	Body	Body Control Module																																																												
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																																												
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2014	Yukon XL	Body	Passenger Presence Module																																																												
2	2014	Yukon XL	Body	Instrument Cluster																																																												
2	2014	Yukon XL	Body	Base Radio																																																												
2	2014	Yukon XL	Body	Navigation Radio																																																												
2	2014	Yukon XL	Body	Uplevel Radio																																																												
2	2014	Yukon XL	Body	Amplifier																																																												
2	2014	Yukon XL	Body	Rear Audio Control Module																																																												
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																																												
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																																												
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																																												
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																																												
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																																												
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																																												
2	2014	Yukon XL	Body	Liftgate Control Module																																																												
2	2014	Yukon XL	Body	Seat Memory Control Module																																																												
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																																												
2	2014	Yukon XL	Body	Assist Step Control Module																																																												
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																																												
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																																												
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																																												
2	2014	Yukon XL	Body	Parking Assist Control Module																																																												
2	2014	Yukon XL	Body	Theft Deterrent Module																																																												
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																											
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																							V																																					
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																							V																																					
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																												
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module							V																		V	V	V	V	V	V	V	V																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																																												
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																								V																																				
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																																												
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2015	Sierra	Chassis	Electronic Brake Control Module																																																												
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																																												
2	2015	Sierra	Chassis	Power Steering Control Module																																																												
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2015	Sierra	Chassis	Suspension Control Module																																																												
2	2015	Sierra	Body	Body Control Module																																																												
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2015	Sierra	Body	Passenger Presence Module																																																												
2	2015	Sierra	Body	Instrument Cluster																																																												
2	2015	Sierra	Body	Radio Controls																																																												
2	2015	Sierra	Body	HVAC Controls																																																												
2	2015	Sierra	Body	Radio																																																												
2	2015	Sierra	Body	Amplifier																																																												
2	2015	Sierra	Body	Media Disc Player																																																												
2	2015	Sierra	Body	Human Machine Interface Control Module																																																												
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																																												
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																												
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																												
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																												
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																												
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																												
2	2015	Sierra	Body	Parking Assist Control Module																																																												
2	2015	Sierra	Body	Frontview Camera Module																																																												
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																																											
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																																											
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																																											
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																																											
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																																											
2	2015	Yukon	Chassis	Electronic Brake Control Module																																																											
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																																											
2	2015	Yukon	Chassis	Parking Brake Control Module																																																											
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																																											
2	2015	Yukon	Chassis	Power Steering Control Module																																																											
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2015	Yukon	Chassis	Suspension Control Module																																																											
2	2015	Yukon	Body	Body Control Module																																																											
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2015	Yukon	Body	Passenger Presence Module																																																											
2	2015	Yukon	Body	Instrument Cluster																																																											
2	2015	Yukon	Body	Radio Controls																																																											
2	2015	Yukon	Body	HVAC Controls																																																											
2	2015	Yukon	Body	Radio																																																											
2	2015	Yukon	Body	Amplifier																																																											
2	2015	Yukon	Body	Media Disc Player																																																											
2	2015	Yukon	Body	Human Machine Interface Control Module																																																											
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																																											
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																																											
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2015	Yukon	Body	HVAC Control Module																																																											
2	2015	Yukon	Body	Liftgate Control Module																																																											
2	2015	Yukon	Body	Keyless Entry Control Module																																																											
2	2015	Yukon	Body	Assist Step Control Module																																																											
2	2015	Yukon	Body	Left Side Object Detection Control Module																																																											
2	2015	Yukon	Body	Parking Assist Control Module																																																											
2	2015	Yukon	Body	Frontview Camera Module																																																											
2	2015	Yukon	Body	Steering Column Lock Control Module																																																											
2	2015	Yukon	Body	Battery Energy Control Module																																																											
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																											
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																																											
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																																											
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																																											
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																																											
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																										
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																																										
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																																										
2	2015	Yukon XL	Chassis	Power Steering Control Module																																																										
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																										
2	2015	Yukon XL	Chassis	Suspension Control Module																																																										
2	2015	Yukon XL	Body	Body Control Module																																																										
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
2	2015	Yukon XL	Body	Passenger Presence Module																																																										
2	2015	Yukon XL	Body	Instrument Cluster																																																										
2	2015	Yukon XL	Body	Radio Controls																																																										
2	2015	Yukon XL	Body	HVAC Controls																																																										
2	2015	Yukon XL	Body	Radio																																																										
2	2015	Yukon XL	Body	Amplifier																																																										
2	2015	Yukon XL	Body	Media Disc Player																																																										
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																																										
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																																										
2	2015	Yukon XL	Body	HVAC Control Module																																																										
2	2015	Yukon XL	Body	Liftgate Control Module																																																										
2	2015	Yukon XL	Body	Keyless Entry Control Module																																																										
2	2015	Yukon XL	Body	Assist Step Control Module																																																										
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																																										
2	2015	Yukon XL	Body	Parking Assist Control Module																																																										
2	2015	Yukon XL	Body	Frontview Camera Module																																																										
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																																										
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																																										
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																															V	V	V																									
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																																										
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																							V																																			
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																							V																																			
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																																										
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																										
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module							V																	V	V	V	V	V	V	V	V																											
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																																										
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																								V																																		
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																										
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2016	Sierra	Chassis	Electronic Brake Control Module																																																											
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																																											
2	2016	Sierra	Chassis	Parking Brake Control Module																																																											
2	2016	Sierra	Chassis	Power Steering Control Module																																			V	V	V																					
2	2016	Sierra	Chassis	Power Steering Control Module																																																											
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2016	Sierra	Chassis	Suspension Control Module																																																											
2	2016	Sierra	Body	Body Control Module																																																											
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2016	Sierra	Body	Passenger Presence Module																																																											
2	2016	Sierra	Body	Instrument Cluster																																																											
2	2016	Sierra	Body	Radio Controls																																																											
2	2016	Sierra	Body	HVAC Controls																																																											
2	2016	Sierra	Body	Radio (IO3)																																																											
2	2016	Sierra	Body	Radio (IOB)																																																											
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																																											
2	2016	Sierra	Body	Amplifier																																																											
2	2016	Sierra	Body	Media Disc Player																																																											
2	2016	Sierra	Body	Human Machine Interface Control Module																																																											
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																																											
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																																											
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																																											
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																																											
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																																											
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																																											
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																																											
2	2016	Sierra	Body	Left Side Object Detection Control Module																																																											
2	2016	Sierra	Body	Parking Assist Control Module																																																											
2	2016	Sierra	Body	Frontview Camera Module																																																											
2	2016	Sierra	Body	Frontview Camera Module																																																											
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																																											
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																																											
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																																											
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																											
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																											
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																											
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																											
2	2016	Yukon	Chassis	Electronic Brake Control Module																																																											
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																																											
2	2016	Yukon	Chassis	Parking Brake Control Module																																																											
2	2016	Yukon	Chassis	Power Steering Control Module																																																											
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																																											
2	2016	Yukon	Chassis	Suspension Control Module																																																											
2	2016	Yukon	Body	Body Control Module																																																											
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
2	2016	Yukon	Body	Passenger Presence Module																																																											
2	2016	Yukon	Body	Instrument Cluster																																																											
2	2016	Yukon	Body	Radio Controls																																																											
2	2016	Yukon	Body	HVAC Controls																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
2	2016	Yukon	Body	Radio																																																												
2	2016	Yukon	Body	Amplifier																																																												
2	2016	Yukon	Body	Media Disc Player																																																												
2	2016	Yukon	Body	Human Machine Interface Control Module																																																												
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																																												
2	2016	Yukon	Body	HVAC Control Module																																																												
2	2016	Yukon	Body	Liftgate Control Module																																																												
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																																												
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																																												
2	2016	Yukon	Body	Keyless Entry Control Module																																																												
2	2016	Yukon	Body	Assist Step Control Module																																																												
2	2016	Yukon	Body	Left Side Object Detection Control Module																																																												
2	2016	Yukon	Body	Parking Assist Control Module																																																												
2	2016	Yukon	Body	Frontview Camera Module																																																												
2	2016	Yukon	Body	Steering Column Lock Control Module																																																												
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																																												
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																																												
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																																												
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																																												
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																																												
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																																												
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																																												
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																																												
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																																												
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																																												
2	2016	Yukon XL	Chassis	Power Steering Control Module																																																												
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																																												
2	2016	Yukon XL	Chassis	Suspension Control Module																																																												
2	2016	Yukon XL	Body	Body Control Module																																																												
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
2	2016	Yukon XL	Body	Passenger Presence Module																																																												
2	2016	Yukon XL	Body	Instrument Cluster																																																												
2	2016	Yukon XL	Body	Radio Controls																																																												
2	2016	Yukon XL	Body	HVAC Controls																																																												
2	2016	Yukon XL	Body	Radio																																																												
2	2016	Yukon XL	Body	Amplifier																																																												
2	2016	Yukon XL	Body	Media Disc Player																																																												
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																																												
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																																												
2	2016	Yukon XL	Body	HVAC Control Module																																																												
2	2016	Yukon XL	Body	Liftgate Control Module																																																												
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																																												
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																																												
2	2016	Yukon XL	Body	Keyless Entry Control Module																																																												
2	2016	Yukon XL	Body	Assist Step Control Module																																																												
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																																												
2	2016	Yukon XL	Body	Parking Assist Control Module																																																												
2	2016	Yukon XL	Body	Frontview Camera Module																																																												
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																																												
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																										
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
5	2011	ALL	Chassis	Electronic Brake Control Module																																																											
5	2011	ALL	Body	Body Control Module																																																											V
5	2011	ALL	Body	Digital Radio Receiver																																																											
5	2011	ALL	Body	Generator Battery Control Module																																																											
5	2011	ALL	Body	Instrument Panel Cluster																																																											
5	2011	ALL	Body	Passenger Presence System																																																											
5	2011	ALL	Body	Personal Audio Link Module																																																											
5	2011	ALL	Body	Base Radio																																																											
5	2011	ALL	Body	Uplevel Radio																																																											
5	2011	ALL	Body	Supplemental Inflatable Restraint																																																											
5	2011	ALL	Body	Theft Deterrent Module																																																											
5	2011	ALL	Body	Vehicle Comm. Interface Module																																																											
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
5	2012	ALL	Chassis	Electronic Brake Control Module																																																											
5	2012	ALL	Body	Body Control Module																																																											V
5	2012	ALL	Body	Digital Radio Receiver																																																											
5	2012	ALL	Body	Generator Battery Control Module																																																											
5	2012	ALL	Body	Instrument Panel Cluster																																																											
5	2012	ALL	Body	Passenger Presence System																																																											
5	2012	ALL	Body	Personal Audio Link Module																																																											
5	2012	ALL	Body	Base Radio																																																											
5	2012	ALL	Body	Uplevel Radio																																																											
5	2012	ALL	Body	Supplemental Inflatable Restraint																																																											
5	2012	ALL	Body	Theft Deterrent Module																																																											
5	2012	ALL	Body	Vehicle Comm. Interface Module																																																											
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
5	2015	Canyon	Powertrain	Chassis Control Module																																																											
5	2015	Canyon	Powertrain	Transfer Case Control Module																																																											
5	2015	Canyon	Chassis	Electronic Brake Control Module																																																											
5	2015	Canyon	Chassis	Power Steering Control Module																																																											
5	2015	Canyon	Body	Body Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
5	2015	Canyon	Body	Passenger Presence Module																																																											
5	2015	Canyon	Body	Radio																																																										
5	2015	Canyon	Body	Amplifier																																																										
5	2015	Canyon	Body	Human Machine Interface Control Module																																																											
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																																											
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																											
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																											
5	2015	Canyon	Body	Parking Assist Control Module																																																											
5	2015	Canyon	Body	Frontview Camera Module																																																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																											
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																											
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																											
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
5	2016	Canyon	Powertrain	Transfer Case Control Module																																																											
5	2016	Canyon	Chassis	Electronic Brake Control Module																																																											
5	2016	Canyon	Chassis	Power Steering Control Module																																																											
5	2016	Canyon	Body	Body Control Module																																																											
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
5	2016	Canyon	Body	Passenger Presence Module																																																											
5	2016	Canyon	Body	Trailer Interface Control Module																																																											
5	2016	Canyon	Body	Radio																																																											
5	2016	Canyon	Body	Amplifier																																																											
5	2016	Canyon	Body	Human Machine Interface Control Module																																																											
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																																											
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																											
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																											
5	2016	Canyon	Body	Frontview Camera Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																											
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																											
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																											
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																											
6	2011	ALL	Chassis	Electronic Brake Control Module																																																											
6	2011	ALL	Body	Body Control Module																																																											
6	2011	ALL	Body	Digital Radio Receiver																																																											
6	2011	ALL	Body	Generator Battery Control Module																																																											
6	2011	ALL	Body	Instrument Panel Cluster																																																											
6	2011	ALL	Body	Passenger Presence System																																																											
6	2011	ALL	Body	Personal Audio Link Module																																																											
6	2011	ALL	Body	Base Radio																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
6	2011	ALL	Body	Uplevel Radio																																																											
6	2011	ALL	Body	Supplemental Inflatable Restraint																																																												
6	2011	ALL	Body	Theft Deterrent Module																																																												
6	2011	ALL	Body	Vehicle Comm. Interface Module																																																												
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																																												
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																																												
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																																												
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																																												
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																																												
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																																												
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																																												
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																																												
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																																												
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																																												
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																																												
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																																												
6	2012	ALL	Chassis	Electronic Brake Control Module																																																													
6	2012	ALL	Body	Body Control Module																																																						V								
6	2012	ALL	Body	Digital Radio Receiver																																																												
6	2012	ALL	Body	Generator Battery Control Module																																																												
6	2012	ALL	Body	Instrument Panel Cluster																																																												
6	2012	ALL	Body	Passenger Presence System																																																												
6	2012	ALL	Body	Personal Audio Link Module																																																												
6	2012	ALL	Body	Base Radio																																																												
6	2012	ALL	Body	Uplevel Radio																																																												
6	2012	ALL	Body	Supplemental Inflatable Restraint																																																												
6	2012	ALL	Body	Theft Deterrent Module																																																												
6	2012	ALL	Body	Vehicle Comm. Interface Module																																																												
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																																											
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																																											
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																											
6	2015	Canyon	Powertrain	Chassis Control Module																																																											
6	2015	Canyon	Powertrain	Transfer Case Control Module																																																											
6	2015	Canyon	Chassis	Electronic Brake Control Module																																																											
6	2015	Canyon	Chassis	Power Steering Control Module																																																											
6	2015	Canyon	Body	Body Control Module																																																											
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
6	2015	Canyon	Body	Passenger Presence Module																																																											
6	2015	Canyon	Body	Radio																																																											
6	2015	Canyon	Body	Amplifier																																																											
6	2015	Canyon	Body	Human Machine Interface Control Module																																																											
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																																											
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																																											
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																																											
6	2015	Canyon	Body	Parking Assist Control Module																																																											
6	2015	Canyon	Body	Frontview Camera Module																																																											
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																																											
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																																											
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																																												
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																																												
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																																												
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																																												
6	2016	Canyon	Powertrain	Transfer Case Control Module																																																												
6	2016	Canyon	Chassis	Electronic Brake Control Module																																																												
6	2016	Canyon	Chassis	Power Steering Control Module																																																												
6	2016	Canyon	Body	Body Control Module																																																												
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
6	2016	Canyon	Body	Passenger Presence Module																																																												
6	2016	Canyon	Body	Trailer Interface Control Module																																																												
6	2016	Canyon	Body	Radio																																																												
6	2016	Canyon	Body	Amplifier																																																												
6	2016	Canyon	Body	Human Machine Interface Control Module																																																												
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																																												
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																																												
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																																												
6	2016	Canyon	Body	Frontview Camera Module																																																												
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																															
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																										
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																												
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																												
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																												
7	2011	Express/Savana	Body	Body Control Module																																																												
7	2011	Express/Savana	Body	Digital Radio Receiver																																																												
7	2011	Express/Savana	Body	Instrument Panel Cluster																																																												
7	2011	Express/Savana	Body	Passenger Presence System																																																												
7	2011	Express/Savana	Body	Radio																																																												
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																												
7	2011	Express/Savana	Body	Rollover Sensor																																																												
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																												
7	2011	Express/Savana	Body	Theft Deterrent Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																												
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																														
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																														
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																														
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																															
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																	
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																												
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																														
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																														
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																														
7	2011	Express Access/Savana Pro	Body	Body Control Module																																																														
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																														
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																														
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																														
7	2011	Express Access/Savana Pro	Body	Radio																																																														
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																														
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																														
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																														
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																														
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																														
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																														
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																														
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																														
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																														
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																														
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																														
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																														
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																																	
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																												
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																														
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																														
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																														
7	2012	Express/Savana	Body	Body Control Module																																																														
7	2012	Express/Savana	Body	Digital Radio Receiver																																																														
7	2012	Express/Savana	Body	Instrument Panel Cluster																																																														
7	2012	Express/Savana	Body	Passenger Presence System																																																														
7	2012	Express/Savana	Body	Radio																																																														
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																														
7	2012	Express/Savana	Body	Rollover Sensor																																																														
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																														
7	2012	Express/Savana	Body	Theft Deterrent Module																																																														
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																														
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																														
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																														
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																														
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V	V	V	V	V	V																																												
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																									
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																										
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2012	Express Access/Savana Pro	Body	Body Control Module																																																										
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																										
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																										
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																										
7	2012	Express Access/Savana Pro	Body	Radio																																																										
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																										
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																										
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																										
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																										
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																										
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																										
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V					V						V																																						
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																									
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																										
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																										
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																										
7	2013	Express/Savana	Body	Body Control Module																																																										
7	2013	Express/Savana	Body	Digital Radio Receiver																																																										
7	2013	Express/Savana	Body	Instrument Panel Cluster																																																										
7	2013	Express/Savana	Body	Passenger Presence System																																																										
7	2013	Express/Savana	Body	Radio																																																										
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																										
7	2013	Express/Savana	Body	Rollover Sensor																																																										
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																										
7	2013	Express/Savana	Body	Theft Deterrent Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																																												
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module							V	V	V					V							V																																							
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module															V	V	V																																									
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																																											
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
7	2013	Express Access/Savana Pro	Body	Body Control Module																																																											
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																											
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																																											
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																																											
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																											
7	2013	Express Access/Savana Pro	Body	Radio																																																											
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																											
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																											
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																							V	V	V																		
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																											
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																											
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																											
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																											
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																							V	V	V																		
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																											
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																											
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																											
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																											
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module							V																		V	V	V	V	V	V	V	V																											
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																											
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																											
7	2014	Savana	Chassis	Electronic Brake Control Module																																																											
7	2014	Savana	Body	Body Control Module																																																											
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																											
7	2014	Savana	Body	Passenger Presence Module																																																											
7	2014	Savana	Body	Rollover Sensor Module																																																											
7	2014	Savana	Body	Instrument Cluster																																																											
7	2014	Savana	Body	Chime Alarm Control Module																																																											
7	2014	Savana	Body	Base Radio																																																											
7	2014	Savana	Body	Navigation Radio																																																											
7	2014	Savana	Body	Uplevel Radio																																																											
7	2014	Savana	Body	Digital Radio Receiver Control Module																																																											
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																											
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
7	2014	Savana	Body	Auxiliary Heater Control Module																																																										
7	2014	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2014	Savana	Body	Parking Assist Control Module																																																										
7	2014	Savana	Body	Theft Deterrent Module																																																										
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																										
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																											
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2015	Savana	Chassis	Electronic Brake Control Module																																																										
7	2015	Savana	Body	Body Control Module																																																										
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2015	Savana	Body	Rollover Sensor Module																																																										
7	2015	Savana	Body	Instrument Cluster																																																										
7	2015	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																										
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																										
7	2015	Savana	Body	Auxiliary Heater Control Module																																																										
7	2015	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2015	Savana	Body	Parking Assist Control Module																																																										
7	2015	Savana	Body	Theft Deterrent Module																																																										
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																										
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																										
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																							V																																			
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																											
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																										
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																										
7	2016	Savana	Chassis	Electronic Brake Control Module																																																										
7	2016	Savana	Body	Body Control Module																																																										
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																										
7	2016	Savana	Body	Instrument Cluster																																																										
7	2016	Savana	Body	Chime Alarm Control Module																																																										
7	2016	Savana	Body	Digital Radio Receiver Control Module																																																										
7	2016	Savana	Body	Telematics Communication Interface Control Module																																																										
7	2016	Savana	Body	Auxiliary Heater Control Module																																																										
7	2016	Savana	Body	Remote Control Door Lock Receiver																																																										
7	2016	Savana	Body	Parking Assist Control Module																																																										
7	2016	Savana	Body	Theft Deterrent Module																																																										
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																										
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																										
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																										

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																										
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
8	2011	Express/Savana	Body	Body Control Module																																																											
8	2011	Express/Savana	Body	Digital Radio Receiver																																																											
8	2011	Express/Savana	Body	Instrument Panel Cluster																																																											
8	2011	Express/Savana	Body	Passenger Presence System																																																											
8	2011	Express/Savana	Body	Radio																																																											
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
8	2011	Express/Savana	Body	Rollover Sensor																																																											
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
8	2011	Express/Savana	Body	Theft Deterrent Module																																																											
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
8	2011	Express Access/Savana Pro	Body	Body Control Module																																																											
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																																											
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																																											
8	2011	Express Access/Savana Pro	Body	Radio																																																											
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																																											
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
8	2012	Express/Savana	Body	Body Control Module																																																											
8	2012	Express/Savana	Body	Digital Radio Receiver																																																											
8	2012	Express/Savana	Body	Instrument Panel Cluster																																																											
8	2012	Express/Savana	Body	Passenger Presence System																																																											
8	2012	Express/Savana	Body	Radio																																																											
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
8	2012	Express/Savana	Body	Rollover Sensor																																																											
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
8	2012	Express/Savana	Body	Theft Deterrent Module																																																											
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																											
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																											
8	2012	Express Access/Savana Pro	Body	Body Control Module																																																												
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																											
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																																											
8	2012	Express Access/Savana Pro	Body	Radio																																																											
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																											
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																																											
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																											
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																																											
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																											
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																											
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																											
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																																											
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																																											
8	2013	Express/Savana	Body	Body Control Module																																																											
8	2013	Express/Savana	Body	Digital Radio Receiver																																																											
8	2013	Express/Savana	Body	Instrument Panel Cluster																																																											
8	2013	Express/Savana	Body	Navigation Radio																																																											
8	2013	Express/Savana	Body	Park Assist Module																																																											
8	2013	Express/Savana	Body	Passenger Presence System																																																											
8	2013	Express/Savana	Body	Radio																																																											
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																																											
8	2013	Express/Savana	Body	Rollover Sensor																																																											
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																																											
8	2013	Express/Savana	Body	Theft Deterrent Module																																																											
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																																											
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																																											
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																																											
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																																											
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																																											
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																																											

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																																												
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																																												
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																																												
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																																												
8	2013	Express Access/Savana Pro	Body	Body Control Module																																																												
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																																												
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																																												
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																																												
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																																												
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																																												
8	2013	Express Access/Savana Pro	Body	Radio																																																												
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																																												
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																																												
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																																												
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																																												
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																																												
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																							V	V	V																		
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																																												
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																																												
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																																												
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																							V	V	V																		
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																												
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																												
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																												
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																												
8	2014	Savana	Chassis	Electronic Brake Control Module																																																												
8	2014	Savana	Body	Body Control Module																																																												
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																												
8	2014	Savana	Body	Passenger Presence Module																																																												
8	2014	Savana	Body	Rollover Sensor Module																																																												
8	2014	Savana	Body	Instrument Cluster																																																												
8	2014	Savana	Body	Chime Alarm Control Module																																																												
8	2014	Savana	Body	Base Radio																																																												
8	2014	Savana	Body	Navigation Radio																																																												
8	2014	Savana	Body	Uplevel Radio																																																												
8	2014	Savana	Body	Digital Radio Receiver Control Module																																																												
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																																												
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																																												
8	2014	Savana	Body	Auxiliary Heater Control Module																																																												
8	2014	Savana	Body	Remote Control Door Lock Receiver																																																												
8	2014	Savana	Body	Parking Assist Control Module																																																												
8	2014	Savana	Body	Theft Deterrent Module																																																												
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																												
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																												
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																												
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																																												
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																													
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																														
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																													
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
8	2015	Savana	Chassis	Electronic Brake Control Module																																																													
8	2015	Savana	Body	Body Control Module																																																													
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
8	2015	Savana	Body	Rollover Sensor Module																																																													
8	2015	Savana	Body	Instrument Cluster																																																													
8	2015	Savana	Body	Digital Radio Receiver Control Module																																																													
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																																													
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																																													
8	2015	Savana	Body	Auxiliary Heater Control Module																																																													
8	2015	Savana	Body	Remote Control Door Lock Receiver																																																													
8	2015	Savana	Body	Parking Assist Control Module																																																													
8	2015	Savana	Body	Theft Deterrent Module																																																													
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																																													
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																																													
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																																													
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																																													
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																						V																																							
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																																													
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module							V																	V	V	V	V	V	V	V	V																														
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																																													
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																																													
8	2016	Savana	Chassis	Electronic Brake Control Module																																																													
8	2016	Savana	Body	Body Control Module																																																													
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																																													
8	2016	Savana	Body	Instrument Cluster																																																													
8	2016	Savana	Body	Chime Alarm Control Module																																																													
8	2016	Savana	Body	Digital Radio Receiver Control Module																																																													
8	2016	Savana	Body	Telematics Communication Interface Control Module																																																													
8	2016	Savana	Body	Auxiliary Heater Control Module																																																													
8	2016	Savana	Body	Remote Control Door Lock Receiver																																																													
8	2016	Savana	Body	Parking Assist Control Module																																																													
8	2016	Savana	Body	Theft Deterrent Module																																																													
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																													
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																													
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																													
ALL	2004	ALL	Chassis	ABS																																																														
ALL	2004	ALL	Chassis	Air Suspension																																																													
ALL	2004	ALL	Body	Amplifier (Bose)																																																													
ALL	2004	ALL	Body	Body Control Module																																																													
ALL	2004	ALL	Body	Digital Radio Receiver																																																													
ALL	2004	ALL	Body	Driver Door Module																																																													
ALL	2004	ALL	Body	Driver Seat Module																																																													
ALL	2004	ALL	Body	Heating and Air Conditioning																																																													
ALL	2004	ALL	Body	Instrument Panel Cluster																																																													
ALL	2004	ALL	Body	OnStar																																																													
ALL	2004	ALL	Body	Passenger Door Module																																																													

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
ALL	2004	ALL	Body	Uplevel Radio																																																														
ALL	2004	ALL	Body	Navigation Radio																																																															
ALL	2004	ALL	Body	Rear Seat Audio																																																															
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																																															
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																															
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																															
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																															
ALL	2005	ALL	Chassis	ABS																																																																
ALL	2005	ALL	Chassis	Air Suspension																																																																
ALL	2005	ALL	Body	Body Control Module																																																																
ALL	2005	ALL	Body	Digital Radio Receiver																																																																
ALL	2005	ALL	Body	Driver Door Module (SUV)																																																																
ALL	2005	ALL	Body	Driver Door Module (SUT)																																																																
ALL	2005	ALL	Body	Driver Seat Module																																																																
ALL	2005	ALL	Body	Heating and Air Conditioning																																																																
ALL	2005	ALL	Body	Instrument Panel Cluster																																																																
ALL	2005	ALL	Body	Passenger Door Module																																																																
ALL	2005	ALL	Body	Uplevel Radio																																																																
ALL	2005	ALL	Body	Navigation Radio																																																																
ALL	2005	ALL	Body	Rear Seat Audio																																																																
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																																															
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																															
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																															
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																															
ALL	2006	H2	Chassis	ABS																																																																
ALL	2006	H2	Chassis	Air Suspension																																																																
ALL	2006	H2	Body	Body Control Module																																																																
ALL	2006	H2	Body	Digital Radio Receiver																																																																
ALL	2006	H2	Body	Driver Door Module (SUV)																																																																
ALL	2006	H2	Body	Driver Door Module (SUT)																																																																
ALL	2006	H2	Body	Driver Seat Module																																																																
ALL	2006	H2	Body	Heating and Air Conditioning																																																																
ALL	2006	H2	Body	Instrument Panel Cluster																																																																
ALL	2006	H2	Body	Passenger Door Module																																																																
ALL	2006	H2	Body	Uplevel Radio																																																																
ALL	2006	H2	Body	Navigation Radio																																																																
ALL	2006	H2	Body	Rear Seat Audio																																																																
ALL	2006	H2	Body	Supplemental Inflatable Restraint																																																															
ALL	2006	H3	Powertrain	Engine Control Module																																																																
ALL	2006	H3	Powertrain	Transmission Control Module																																																																
ALL	2006	H3	Powertrain	Transfer Case Control Module																																																																
ALL	2006	H3	Chassis	Antilock Brake System																																																																
ALL	2006	H3	Body	Body Control Module																																																																
ALL	2006	H3	Body	Digital Radio Receiver																																																																
ALL	2006	H3	Body	Instrument Panel Cluster																																																																
ALL	2006	H3	Body	Uplevel Radio																																																																
ALL	2006	H3	Body	Navigation Radio																																																																
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																																															
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																																															
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																																															
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																																															

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
ALL	2007	H2	Chassis	ABS																																																												
ALL	2007	H2	Chassis	Air Suspension																																																												
ALL	2007	H2	Body	Amplifier (Bose)																																																												
ALL	2007	H2	Body	Body Control Module																																																												
ALL	2007	H2	Body	Digital Radio Receiver																																																												
ALL	2007	H2	Body	Driver Door Module (SUV)																																																												
ALL	2007	H2	Body	Driver Door Module (SUT)																																																												
ALL	2007	H2	Body	Driver Seat Module																																																												
ALL	2007	H2	Body	HVAC Control Module																																																												
ALL	2007	H2	Body	Instrument Panel Cluster																																																												
ALL	2007	H2	Body	Passenger Door Module																																																												
ALL	2007	H2	Body	Uplevel Radio																																																												
ALL	2007	H2	Body	Navigation Radio																																																												
ALL	2007	H2	Body	Rear Seat Audio																																																												
ALL	2007	H2	Body	Supplemental Inflatable Restraint																																																												
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																																												
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																												
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																												
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																												
ALL	2007	H3	Chassis	EBCM																																																												
ALL	2007	H3	Body	Body Control Module (5GT)																																																												
ALL	2007	H3	Body	Body Control Module (ADM)																																																												
ALL	2007	H3	Body	Digital Radio Receiver																																																												
ALL	2007	H3	Body	Generator Battery Control Module																																																												
ALL	2007	H3	Body	Instrument Panel Cluster																																																												
ALL	2007	H3	Body	Personal Audio Link Module																																																												
ALL	2007	H3	Body	Uplevel Radio																																																												
ALL	2007	H3	Body	Navigation Radio																																																												
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																																												
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																												
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																												
ALL	2008	H2	Chassis	Air SCM																																																												
ALL	2008	H2	Chassis	EBCM																																																												
ALL	2008	H2	Body	Amplifier (Bose)																																																												
ALL	2008	H2	Body	Body Control Module																																																												
ALL	2008	H2	Body	Digital Radio Receiver																																																												
ALL	2008	H2	Body	Driver Door Switch																																																												
ALL	2008	H2	Body	HVAC Control Module																																																												
ALL	2008	H2	Body	Instrument Panel Cluster																																																												
ALL	2008	H2	Body	Memory Seat Module																																																												
ALL	2008	H2	Body	Passenger Door Switch																																																												
ALL	2008	H2	Body	Radio																																																												
ALL	2008	H2	Body	Rear Heated Seat Module																																																												
ALL	2008	H2	Body	Rear HVAC/RSA																																																												
ALL	2008	H2	Body	Rollover Sensor																																																												
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																																												
ALL	2008	H2	Body	Theft Deterrent Module																																																												
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																										
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																										
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																																										
ALL	2008	H3	Chassis	EBCM																																																										
ALL	2008	H3	Body	Body Control Module (5GT)																																																										V							
ALL	2008	H3	Body	Body Control Module (ADM)																																																										V							
ALL	2008	H3	Body	Digital Radio Receiver																																																														
ALL	2008	H3	Body	Generator Battery Control Module																																																														
ALL	2008	H3	Body	Instrument Panel Cluster																																																														
ALL	2008	H3	Body	Personal Audio Link Module																																																														
ALL	2008	H3	Body	Uplevel Radio																																																														
ALL	2008	H3	Body	Navigation Radio																																																														
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																																														
ALL	2008	H3	Body	Theft Deterrent Module																																																														
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																																														
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																														
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																														
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																														
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																														
ALL	2009	H2	Chassis	Air SCM																																																															
ALL	2009	H2	Chassis	EBCM																																																														
ALL	2009	H2	Body	Amplifier (Bose)																																																														
ALL	2009	H2	Body	Body Control Module																																																														
ALL	2009	H2	Body	Digital Radio Receiver																																																														
ALL	2009	H2	Body	Driver Door Switch																																																														
ALL	2009	H2	Body	HVAC Control Module																																																														
ALL	2009	H2	Body	Instrument Panel Cluster																																																														
ALL	2009	H2	Body	Memory Seat Module																																																														
ALL	2009	H2	Body	Passenger Door Switch																																																														
ALL	2009	H2	Body	Radio																																																														
ALL	2009	H2	Body	Rear Heated Seat Module																																																														
ALL	2009	H2	Body	Rear HVAC/RSA																																																														
ALL	2009	H2	Body	Rollover Sensor																																																														
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																																														
ALL	2009	H2	Body	Theft Deterrent Module																																																														
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																														
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																																														
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)																																																														
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																																														
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																														
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																														
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																														
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																														
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)																																																														
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)																																																														
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																																													
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																																														

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																																												
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																																												
ALL	2009	H3	Chassis	EBCM																																																												
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																																												
ALL	2009	H3	Body	Body Control Module (ADM)																																																												
ALL	2009	H3	Body	Digital Radio Receiver																																																												
ALL	2009	H3	Body	Generator Battery Control Module																																																												
ALL	2009	H3	Body	Instrument Panel Cluster																																																												
ALL	2009	H3	Body	Personal Audio Link Module																																																												
ALL	2009	H3	Body	Uplevel Radio																																																												
ALL	2009	H3	Body	Navigation Radio																																																												
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																																												
ALL	2009	H3	Body	Theft Deterrent Module																																																												
ALL	2009	H3	Body	Vehicle Comm. Interface Module																																																												
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																																												
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																																												
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																																												
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																																												
ALL	2010	H2	Chassis	Air SCM																																																												
ALL	2010	H2	Chassis	EBCM																																																												
ALL	2010	H2	Body	Amplifier (Bose)																																																												
ALL	2010	H2	Body	Body Control Module																																																												
ALL	2010	H2	Body	Digital Radio Receiver																																																												
ALL	2010	H2	Body	Driver Door Switch																																																												
ALL	2010	H2	Body	HVAC Control Module																																																												
ALL	2010	H2	Body	Instrument Panel Cluster																																																												
ALL	2010	H2	Body	Memory Seat Module																																																												
ALL	2010	H2	Body	Passenger Door Switch																																																												
ALL	2010	H2	Body	Personal Audio Link Module																																																												
ALL	2010	H2	Body	Radio																																																												
ALL	2010	H2	Body	Rear Heated Seat Module																																																												
ALL	2010	H2	Body	Rear HVAC/RSA																																																												
ALL	2010	H2	Body	Rollover Sensor																																																												
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																																												
ALL	2010	H2	Body	Theft Deterrent Module																																																												
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																																												
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																																												
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																																												
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																																												
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																																												
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																																												
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module																																																												
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																																												
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																																												
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																																												
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																																												
ALL	2010	H3	Chassis	EBCM																																																												
ALL	2010	H3	Body	Body Control Module																																																												
ALL	2010	H3	Body	Digital Radio Receiver																																																												
ALL	2010	H3	Body	Generator Battery Control Module																																																												
ALL	2010	H3	Body	Instrument Panel Cluster																																																												

Engine type	Year	Model	System 1	System 2	Autostart Inhibit Reasons	Autostop Inhibit Reasons	Acceleration Sensor Reset	Steering Pos./Torque Sensor Cal.	15.Exh. Aftertreatment Data	Code Index	Catalyst 1 Reset	CKP Reluctor Wheel Learn	DPF/ Catalyst 2 Reset	Reset Injection Value - Cyl. 5	Reset Injection Value - Cyl. 6	Reset Injection Value - Cyl. 7	Reset Injection Value - Cyl. 8	NOx Cat. Reductant Loading Reset	Reductant Heater 1	Reductant Heater 2	Reductant Heater 3	Configuration Data	Keyless Entry Antenna - Left Body	Keyless Entry Antenna - Right Body	Ambient Air Temperature Reset	Indicator Data	Camshaft Position Actuator System	Reset PTO Inhibit and Disengage History	Ambient Air Temperature Calculation Reset	DPF/Catalyst 2 Reset	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM	Copy Injector Flow Identifiers from ECM to Glow Plow Control Module	Cylinder 5 Fuel Injector Correction Value Reset	Cylinder 6 Fuel Injector Correction Value Reset	Cylinder 7 Fuel Injector Correction Value Reset	Cylinder 8 Fuel Injector Correction Value Reset	Brake Motor Control Module Data	Drive Motor Control Module Data	On-Board Jump Assist Counter Reset	Steering Gear Learned Values Reset	Power Steering Pressure Sensor Learn	Steering Gear Replacement Procedure	Fuel Trim Data Display	Vehicle Speed Limit	1-2 Shift Adapt Data	2-3 Shift Adapt Data	3-4 Shift Adapt Data	Transfer Case System ID	Module Information 3	Input 1	Input 2	Program Key Fobs	Accessory	Switch Inputs	Door Locks	Option Configuration	Pre-alarm Option	CTD Operation	Door Lock Operation	Fob Feedback
ALL	2010	H3	Body	Personal Audio Link Module																																																																
ALL	2010	H3	Body	Uplevel Radio																																																																
ALL	2010	H3	Body	Navigation Radio																																																																
ALL	2010	H3	Body	Supplemental Inflatable Restraint																																																																
ALL	2010	H3	Body	Theft Deterrent Module																																																																
ALL	2010	H3	Body	Vehicle Comm. Interface Module																																																																

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
C	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
C	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
C	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																								
C	2004	ALL	Powertrain	(R)5.7L V8 L31 Transmission Control Module																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																								
C	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
C	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																								
C	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																								
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
C	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																								
C	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																								
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																								
C	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
C	2004	ALL	Chassis	ABS Over 8600 GVW																																								
C	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																								
C	2004	ALL	Chassis	ESC																																								
C	2004	ALL	Chassis	Rear Wheel Steering																																								
C	2004	ALL	Chassis	Tire Pressure Monitor																																								
C	2004	ALL	Chassis	Traction Assist (If Equipped)																																								
C	2004	ALL	Chassis	VSES																																								
C	2004	ALL	Body	Amplifier (Bose)																																								
C	2004	ALL	Body	Body Control Module																																								
C	2004	ALL	Body	CD Changer																																								
C	2004	ALL	Body	Chime																																								
C	2004	ALL	Body	Driver Door Module																																								
C	2004	ALL	Body	Driver Seat Module																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto																																								
C	2004	ALL	Body	Heating and Air Conditioning Manual																																								
C	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																								
C	2004	ALL	Body	Instrument Panel Cluster																																								
C	2004	ALL	Body	OnStar																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2004	ALL	Body	Passenger Door Module																																								
C	2004	ALL	Body	Passenger Presence System																																								
C	2004	ALL	Body	Radio Base																																								
C	2004	ALL	Body	Radio Uplevel																																								
C	2004	ALL	Body	Radio Navigation																																								
C	2004	ALL	Body	Rear Aux. Climate Module																																								
C	2004	ALL	Body	Rear HVAC																																								
C	2004	ALL	Body	Rear Seat Audio																																								
C	2004	ALL	Body	Rear Seat Entertainment																																								
C	2004	ALL	Body	Supplemental Inflatable Restraint																																								
C	2004	ALL	Body	Vehicle Theft Deterrent																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
C	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																								
C	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																								
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
C	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
C	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
C	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																								
C	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
C	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
C	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																								
C	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																								
C	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																								
C	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																								
C	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
C	2005	ALL	Chassis	ABS Over 8600 GVW																																								
C	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																								
C	2005	ALL	Chassis	ESC																																								
C	2005	ALL	Chassis	Rear Wheel Steering																																								
C	2005	ALL	Chassis	Tire Pressure Monitor																																								
C	2005	ALL	Chassis	Traction Assist (If Equipped)																																								
C	2005	ALL	Chassis	VSES																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2005	ALL	Body	Amplifier (Bose)																																								
C	2005	ALL	Body	Body Control Module																																								
C	2005	ALL	Body	CD Changer																																								
C	2005	ALL	Body	Chime																																								
C	2005	ALL	Body	Disc Player and Video Display																																								
C	2005	ALL	Body	Driver Door Module																																								
C	2005	ALL	Body	Driver Seat Module																																								
C	2005	ALL	Body	Generator Battery Control Module																																								
C	2005	ALL	Body	Heating and Air Conditioning Auto																																								
C	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																								
C	2005	ALL	Body	Heating and Air Conditioning Manual																																								
C	2005	ALL	Body	Instrument Panel Cluster																																								
C	2005	ALL	Body	Passenger Door Module																																								
C	2005	ALL	Body	Passenger Presence System																																								
C	2005	ALL	Body	Base Radio																																								
C	2005	ALL	Body	Uplevel Radio																																								
C	2005	ALL	Body	Navigation Radio																																								
C	2005	ALL	Body	Rear Aux. Climate Module																																								
C	2005	ALL	Body	Rear HVAC																																								
C	2005	ALL	Body	Rear Seat Audio																																								
C	2005	ALL	Body	Supplemental Inflatable Restraint																																								
C	2005	ALL	Body	Vehicle Comm. Interface Module																																								
C	2005	ALL	Body	Vehicle Theft Deterrent																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
C	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																								
C	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																								
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
C	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
C	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
C	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																								
C	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
C	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																								
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																								
C	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
C	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																								
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																								
C	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																								
C	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																								
C	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																								
C	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
C	2006	ALL	Chassis	ABS Over 8600 GVW																																								
C	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																								
C	2006	ALL	Chassis	ESC																																								
C	2006	ALL	Chassis	Tire Pressure Monitor																																								
C	2006	ALL	Chassis	Traction Assist (If Equipped)																																								
C	2006	ALL	Chassis	VSES																																								
C	2006	ALL	Body	Amplifier (Bose)																																								
C	2006	ALL	Body	Body Control Module																																								
C	2006	ALL	Body	CD Changer																																								
C	2006	ALL	Body	Chime																																								
C	2006	ALL	Body	Disc Player and Video Display																																								
C	2006	ALL	Body	Driver Door Module																																								
C	2006	ALL	Body	Driver Seat Module																																								
C	2006	ALL	Body	Generator Battery Control Module																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto																																								
C	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																								
C	2006	ALL	Body	Heating and Air Conditioning Manual																																								
C	2006	ALL	Body	Instrument Panel Cluster																																								
C	2006	ALL	Body	Passenger Door Module																																								
C	2006	ALL	Body	Passenger Presence System																																								
C	2006	ALL	Body	Base Radio																																								
C	2006	ALL	Body	Uplevel Radio																																								
C	2006	ALL	Body	Navigation Radio																																								
C	2006	ALL	Body	Rear Aux. Climate Module																																								
C	2006	ALL	Body	Rear HVAC																																								
C	2006	ALL	Body	Rear Seat Audio																																								
C	2006	ALL	Body	Supplemental Inflatable Restraint																																								
C	2006	ALL	Body	Vehicle Theft Deterrent																																								
C	2006	ALL	Body	Vehicle Comm. Interface Module																																								
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
C	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
C	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
C	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																								
C	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
C	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2007	Sierra	Chassis	Electronic Suspension Control																																								
C	2007	Sierra	Chassis	Trailer Brake Control Module																																								
C	2007	Sierra	Body	Amplifier (Bose)																																								
C	2007	Sierra	Body	Body Control Module																																								
C	2007	Sierra	Body	Body Control Module (aux.)																																								
C	2007	Sierra	Body	Digital Radio Receiver																																								
C	2007	Sierra	Body	Driver Door Switch																																								
C	2007	Sierra	Body	HVAC Control Module Auto																																								
C	2007	Sierra	Body	HVAC Control Module Manual																																								
C	2007	Sierra	Body	Instrument Panel Cluster																																								
C	2007	Sierra	Body	Memory Seat Module																																								
C	2007	Sierra	Body	Park Assist Module																																								
C	2007	Sierra	Body	Passenger Door Switch																																								
C	2007	Sierra	Body	Passenger Presence System																																								
C	2007	Sierra	Body	Radio																																								
C	2007	Sierra	Body	Rear Heated Seat Module																																								
C	2007	Sierra	Body	Rear HVAC/RSA																																								
C	2007	Sierra	Body	Rollover Sensor																																								
C	2007	Sierra	Body	Supplemental Inflatable Restraint																																								
C	2007	Sierra	Body	Theft Deterrent Module																																								
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
C	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
C	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
C	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2007	Yukon	Chassis	Electronic Suspension Control																																								
C	2007	Yukon	Chassis	Trailer Brake Control Module																																								
C	2007	Yukon	Body	Amplifier (Bose)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2007	Yukon	Body	Assist Step Controller																																								
C	2007	Yukon	Body	Body Control Module																																								
C	2007	Yukon	Body	Body Control Module (aux.)																																								
C	2007	Yukon	Body	Digital Radio Receiver																																								
C	2007	Yukon	Body	Driver Door Switch																																								
C	2007	Yukon	Body	HVAC Control Module Auto																																								
C	2007	Yukon	Body	HVAC Control Module Manual																																								
C	2007	Yukon	Body	Instrument Panel Cluster																																								
C	2007	Yukon	Body	Lift Gate Module																																								
C	2007	Yukon	Body	Memory Seat Module																																								
C	2007	Yukon	Body	Park Assist Module																																								
C	2007	Yukon	Body	Passenger Door Switch																																								
C	2007	Yukon	Body	Passenger Presence System																																								
C	2007	Yukon	Body	Radio																																								
C	2007	Yukon	Body	Rear Heated Seat Module																																								
C	2007	Yukon	Body	Rear HVAC/RSA																																								
C	2007	Yukon	Body	Rollover Sensor																																								
C	2007	Yukon	Body	Supplemental Inflatable Restraint																																								
C	2007	Yukon	Body	Theft Deterrent Module																																								
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
C	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2007	Yukon XL	Chassis	Electronic Suspension Control																																								
C	2007	Yukon XL	Chassis	Trailer Brake Control Module																																								
C	2007	Yukon XL	Body	Amplifier (Bose)																																								
C	2007	Yukon XL	Body	Assist Step Controller																																								
C	2007	Yukon XL	Body	Body Control Module																																								
C	2007	Yukon XL	Body	Body Control Module (aux.)																																								
C	2007	Yukon XL	Body	Digital Radio Receiver																																								
C	2007	Yukon XL	Body	Driver Door Switch																																								
C	2007	Yukon XL	Body	HVAC Control Module Auto																																								
C	2007	Yukon XL	Body	HVAC Control Module Manual																																								
C	2007	Yukon XL	Body	Instrument Panel Cluster																																								
C	2007	Yukon XL	Body	Lift Gate Module																																								
C	2007	Yukon XL	Body	Memory Seat Module																																								
C	2007	Yukon XL	Body	Park Assist Module																																								
C	2007	Yukon XL	Body	Passenger Door Switch																																								
C	2007	Yukon XL	Body	Passenger Presence System																																								
C	2007	Yukon XL	Body	Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2007	Yukon XL	Body	Rear Heated Seat Module																																								
C	2007	Yukon XL	Body	Rear HVAC/RSA																																								
C	2007	Yukon XL	Body	Rollover Sensor																																								
C	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																								
C	2007	Yukon XL	Body	Theft Deterrent Module																																								
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
C	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
C	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
C	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																								
C	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
C	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																								
C	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																								
C	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2008	Sierra	Chassis	Electronic Suspension Control																																								
C	2008	Sierra	Chassis	Trailer Brake Control Module																																								
C	2008	Sierra	Body	Amplifier (Bose)																																								
C	2008	Sierra	Body	Body Control Module																																								
C	2008	Sierra	Body	Body Control Module (aux.)																																								
C	2008	Sierra	Body	Digital Radio Receiver																																								
C	2008	Sierra	Body	Driver Door Switch																																								
C	2008	Sierra	Body	HVAC Control Module Auto																																								
C	2008	Sierra	Body	HVAC Control Module Manual																																								
C	2008	Sierra	Body	Instrument Panel Cluster																																								
C	2008	Sierra	Body	Memory Seat Module																																								
C	2008	Sierra	Body	Park Assist Module																																								
C	2008	Sierra	Body	Passenger Door Switch																																								
C	2008	Sierra	Body	Passenger Presence System																																								
C	2008	Sierra	Body	Radio																																								
C	2008	Sierra	Body	Rear Heated Seat Module																																								
C	2008	Sierra	Body	Rear HVAC/RSA																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2008	Sierra	Body	Rollover Sensor																																								
C	2008	Sierra	Body	Supplemental Inflatable Restraint																																								
C	2008	Sierra	Body	Theft Deterrent Module																																								
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
C	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																								
C	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2008	Yukon	Chassis	Electronic Brake Control Module																																								
C	2008	Yukon	Chassis	Electronic Suspension Control																																								
C	2008	Yukon	Chassis	Trailer Brake Control Module																																								
C	2008	Yukon	Body	Amplifier (Bose)																																								
C	2008	Yukon	Body	Assist Step Controller																																								
C	2008	Yukon	Body	Body Control Module																																								
C	2008	Yukon	Body	Body Control Module (aux.)																																								
C	2008	Yukon	Body	Digital Radio Receiver																																								
C	2008	Yukon	Body	Driver Door Switch																																								
C	2008	Yukon	Body	HVAC Control Module Auto																																								
C	2008	Yukon	Body	HVAC Control Module Manual																																								
C	2008	Yukon	Body	Instrument Panel Cluster																																								
C	2008	Yukon	Body	Lift Gate Module																																								
C	2008	Yukon	Body	Memory Seat Module																																								
C	2008	Yukon	Body	Park Assist Module																																								
C	2008	Yukon	Body	Passenger Door Switch																																								
C	2008	Yukon	Body	Passenger Presence System																																								
C	2008	Yukon	Body	Radio																																								
C	2008	Yukon	Body	Rear Heated Seat Module																																								
C	2008	Yukon	Body	Rear HVAC/RSA																																								
C	2008	Yukon	Body	Rollover Sensor																																								
C	2008	Yukon	Body	Supplemental Inflatable Restraint																																								
C	2008	Yukon	Body	Theft Deterrent Module																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																								
C	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																								
C	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																								
C	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																								
C	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																								
C	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2008	Yukon Hybrid	Body	Amplifier (Bose)																																								
C	2008	Yukon Hybrid	Body	Body Control Module																																								
C	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																								
C	2008	Yukon Hybrid	Body	Digital Radio Receiver																																								
C	2008	Yukon Hybrid	Body	Driver Door Switch																																								
C	2008	Yukon Hybrid	Body	HVAC Control Module																																								
C	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																								
C	2008	Yukon Hybrid	Body	Lift Gate Module																																								
C	2008	Yukon Hybrid	Body	Memory Seat Module																																								
C	2008	Yukon Hybrid	Body	Park Assist Module																																								
C	2008	Yukon Hybrid	Body	Passenger Door Switch																																								
C	2008	Yukon Hybrid	Body	Passenger Presence System																																								
C	2008	Yukon Hybrid	Body	Radio																																								
C	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																								
C	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																								
C	2008	Yukon Hybrid	Body	Rollover Sensor																																								
C	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																								
C	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2008	Yukon Hybrid	Body	Theft Deterrent Module																																								
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
C	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																								
C	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																								
C	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2008	Yukon XL	Chassis	Electronic Suspension Control																																								
C	2008	Yukon XL	Chassis	Trailer Brake Control Module																																								
C	2008	Yukon XL	Body	Amplifier (Bose)																																								
C	2008	Yukon XL	Body	Assist Step Controller																																								
C	2008	Yukon XL	Body	Body Control Module																																								
C	2008	Yukon XL	Body	Body Control Module (aux.)																																								
C	2008	Yukon XL	Body	Digital Radio Receiver																																								
C	2008	Yukon XL	Body	Driver Door Switch																																								
C	2008	Yukon XL	Body	HVAC Control Module Auto																																								
C	2008	Yukon XL	Body	HVAC Control Module Manual																																								
C	2008	Yukon XL	Body	Instrument Panel Cluster																																								
C	2008	Yukon XL	Body	Lift Gate Module																																								
C	2008	Yukon XL	Body	Memory Seat Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2008	Yukon XL	Body	Park Assist Module																																								
C	2008	Yukon XL	Body	Passenger Door Switch																																								
C	2008	Yukon XL	Body	Passenger Presence System																																								
C	2008	Yukon XL	Body	Radio																																								
C	2008	Yukon XL	Body	Rear Heated Seat Module																																								
C	2008	Yukon XL	Body	Rear HVAC/RSA																																								
C	2008	Yukon XL	Body	Rollover Sensor																																								
C	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																								
C	2008	Yukon XL	Body	Theft Deterrent Module																																								
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
C	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
C	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																								
C	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
C	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
C	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module Manual																																								
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																								
C	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																								
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
C	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
C	2009	Sierra	Chassis	Electronic Suspension Control																																								
C	2009	Sierra	Chassis	Trailer Brake Control Module																																								
C	2009	Sierra	Body	Amplifier (Bose)																																								
C	2009	Sierra	Body	Body Control Module																																								
C	2009	Sierra	Body	Body Control Module (aux.)																																								
C	2009	Sierra	Body	Digital Radio Receiver																																								
C	2009	Sierra	Body	Driver Door Switch																																								
C	2009	Sierra	Body	HVAC Control Module Auto																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2009	Sierra	Body	HVAC Control Module Manual																																								
C	2009	Sierra	Body	Instrument Panel Cluster																																								
C	2009	Sierra	Body	Memory Seat Module																																								
C	2009	Sierra	Body	Park Assist Module																																								
C	2009	Sierra	Body	Passenger Door Switch																																								
C	2009	Sierra	Body	Passenger Presence System																																								
C	2009	Sierra	Body	Radio																																								
C	2009	Sierra	Body	Rear Heated Seat Module																																								
C	2009	Sierra	Body	Rear HVAC/RSA																																								
C	2009	Sierra	Body	Rollover Sensor																																								
C	2009	Sierra	Body	Supplemental Inflatable Restraint																																								
C	2009	Sierra	Body	Theft Deterrent Module																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																								
C	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																								
C	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																								
C	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																								
C	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																								
C	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																								
C	2009	Sierra Hybrid	Body	Amplifier (Bose)																																								
C	2009	Sierra Hybrid	Body	Body Control Module																																								
C	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																								
C	2009	Sierra Hybrid	Body	Digital Radio Receiver																																								
C	2009	Sierra Hybrid	Body	Driver Door Switch																																								
C	2009	Sierra Hybrid	Body	HVAC Control Module																																								
C	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																								
C	2009	Sierra Hybrid	Body	Memory Seat Module																																								
C	2009	Sierra Hybrid	Body	Park Assist Module																																								
C	2009	Sierra Hybrid	Body	Passenger Door Switch																																								
C	2009	Sierra Hybrid	Body	Passenger Presence System																																								
C	2009	Sierra Hybrid	Body	Radio																																								
C	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																								
C	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																								
C	2009	Sierra Hybrid	Body	Rollover Sensor																																								
C	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																								
C	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2009	Sierra Hybrid	Body	Theft Deterrent Module																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 6 Speed																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module 4 Speed																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																								
C	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																								
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
C	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 6 Speed																																								
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module 4 Speed																																								
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																								
C	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																								
C	2009	Yukon	Chassis	Electronic Brake Control Module																																								
C	2009	Yukon	Chassis	Electronic Suspension Control																																								
C	2009	Yukon	Chassis	Trailer Brake Control Module																																								
C	2009	Yukon	Body	Amplifier (Bose)																																								
C	2009	Yukon	Body	Assist Step Controller																																								
C	2009	Yukon	Body	Body Control Module																																								
C	2009	Yukon	Body	Body Control Module (aux.)																																								
C	2009	Yukon	Body	Digital Radio Receiver																																								
C	2009	Yukon	Body	Driver Door Switch																																								
C	2009	Yukon	Body	HVAC Control Module Auto																																								
C	2009	Yukon	Body	HVAC Control Module Manual																																								
C	2009	Yukon	Body	Instrument Panel Cluster																																								
C	2009	Yukon	Body	Left Side Object Detection Module																																								
C	2009	Yukon	Body	Lift Gate Module																																								
C	2009	Yukon	Body	Memory Seat Module																																								
C	2009	Yukon	Body	Park Assist Module																																								
C	2009	Yukon	Body	Passenger Door Switch																																								
C	2009	Yukon	Body	Passenger Presence System																																								
C	2009	Yukon	Body	Radio																																								
C	2009	Yukon	Body	Rear Heated Seat Module																																								
C	2009	Yukon	Body	Rear HVAC/RSA																																								
C	2009	Yukon	Body	Right Side Object Detection Module																																								
C	2009	Yukon	Body	Rollover Sensor																																								
C	2009	Yukon	Body	Supplemental Inflatable Restraint																																								
C	2009	Yukon	Body	Theft Deterrent Module																																								
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																								
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																								
C	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
C	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																								
C	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																								
C	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																								
C	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																								
C	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																								
C	2009	Yukon Hybrid	Body	Amplifier (Bose)																																								
C	2009	Yukon Hybrid	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																								
C	2009	Yukon Hybrid	Body	Digital Radio Receiver																																								
C	2009	Yukon Hybrid	Body	Driver Door Switch																																								
C	2009	Yukon Hybrid	Body	Heated Seat Module																																								
C	2009	Yukon Hybrid	Body	HVAC Control Module																																								
C	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																								
C	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																								
C	2009	Yukon Hybrid	Body	Park Assist Module																																								
C	2009	Yukon Hybrid	Body	Passenger Door Switch																																								
C	2009	Yukon Hybrid	Body	Passenger Presence System																																								
C	2009	Yukon Hybrid	Body	Radio																																								
C	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																								
C	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																								
C	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																								
C	2009	Yukon Hybrid	Body	Rollover Sensor																																								
C	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																								
C	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2009	Yukon Hybrid	Body	Theft Deterrent Module																																								
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
C	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
C	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																								
C	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																								
C	2009	Yukon XL	Chassis	Electronic Suspension Control																																								
C	2009	Yukon XL	Chassis	Trailer Brake Control Module																																								
C	2009	Yukon XL	Body	Amplifier (Bose)																																								
C	2009	Yukon XL	Body	Assist Step Controller																																								
C	2009	Yukon XL	Body	Body Control Module																																								
C	2009	Yukon XL	Body	Body Control Module (aux.)																																								
C	2009	Yukon XL	Body	Digital Radio Receiver																																								
C	2009	Yukon XL	Body	Driver Door Switch																																								
C	2009	Yukon XL	Body	HVAC Control Module Auto																																								
C	2009	Yukon XL	Body	HVAC Control Module Manual																																								
C	2009	Yukon XL	Body	Instrument Panel Cluster																																								
C	2009	Yukon XL	Body	Left Side Object Detection Module																																								
C	2009	Yukon XL	Body	Lift Gate Module																																								
C	2009	Yukon XL	Body	Memory Seat Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2009	Yukon XL	Body	Park Assist Module																																								
C	2009	Yukon XL	Body	Passenger Door Switch																																								
C	2009	Yukon XL	Body	Passenger Presence System																																								
C	2009	Yukon XL	Body	Radio																																								
C	2009	Yukon XL	Body	Rear Heated Seat Module																																								
C	2009	Yukon XL	Body	Rear HVAC/RSA																																								
C	2009	Yukon XL	Body	Right Side Object Detection Module																																								
C	2009	Yukon XL	Body	Rollover Sensor																																								
C	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																								
C	2009	Yukon XL	Body	Theft Deterrent Module																																								
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
C	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																								
C	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
C	2010	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
C	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
C	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																								
C	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																								
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
C	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
C	2010	Sierra	Chassis	Electronic Suspension Control																																								
C	2010	Sierra	Chassis	Trailer Brake Control Module																																								
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Sierra	Body	Amplifier (Bose)																																								
C	2010	Sierra	Body	Body Control Module																																								
C	2010	Sierra	Body	Body Control Module (aux.)																																								
C	2010	Sierra	Body	Digital Radio Receiver																																								
C	2010	Sierra	Body	Driver Door Switch																																								
C	2010	Sierra	Body	HVAC Control Module Auto																																								
C	2010	Sierra	Body	HVAC Control Module Manual																																								
C	2010	Sierra	Body	Instrument Panel Cluster																																								
C	2010	Sierra	Body	Memory Seat Module																																								
C	2010	Sierra	Body	Park Assist Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2010	Sierra	Body	Passenger Door Switch																																								
C	2010	Sierra	Body	Passenger Presence System																																								
C	2010	Sierra	Body	Radio																																								
C	2010	Sierra	Body	Rear Heated Seat Module																																								
C	2010	Sierra	Body	Rear HVAC/RSA																																								
C	2010	Sierra	Body	Supplemental Inflatable Restraint																																								
C	2010	Sierra	Body	Theft Deterrent Module																																								
C	2010	Sierra Hybrid	Powertrain	Engine Control Module																																								
C	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																								
C	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																								
C	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																								
C	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																								
C	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																								
C	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																								
C	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																								
C	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																								
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																								
C	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																								
C	2010	Sierra Hybrid	Body	Amplifier (Bose)																																								
C	2010	Sierra Hybrid	Body	Body Control Module																																								
C	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																								
C	2010	Sierra Hybrid	Body	Digital Radio Receiver																																								
C	2010	Sierra Hybrid	Body	Driver Door Switch																																								
C	2010	Sierra Hybrid	Body	Heated Seat Module																																								
C	2010	Sierra Hybrid	Body	HVAC Control Module																																								
C	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																								
C	2010	Sierra Hybrid	Body	Park Assist Module																																								
C	2010	Sierra Hybrid	Body	Passenger Door Switch																																								
C	2010	Sierra Hybrid	Body	Passenger Presence System																																								
C	2010	Sierra Hybrid	Body	Radio																																								
C	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																								
C	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																								
C	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																								
C	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																								
C	2010	Sierra Hybrid	Body	Theft Deterrent Module																																								
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
C	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2010	Yukon	Chassis	Electronic Brake Control Module																																								
C	2010	Yukon	Chassis	Electronic Suspension Control																																								
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Yukon	Body	Amplifier (Bose)																																								
C	2010	Yukon	Body	Assist Step Controller																																								
C	2010	Yukon	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2010	Yukon	Body	Body Control Module (aux.)																																								
C	2010	Yukon	Body	Digital Radio Receiver																																								
C	2010	Yukon	Body	Driver Door Switch																																								
C	2010	Yukon	Body	HVAC Control Module Auto																																								
C	2010	Yukon	Body	HVAC Control Module Manual																																								
C	2010	Yukon	Body	Instrument Panel Cluster																																								
C	2010	Yukon	Body	Left Side Object Detection Module																																								
C	2010	Yukon	Body	Lift Gate Module																																								
C	2010	Yukon	Body	Memory Seat Module																																								
C	2010	Yukon	Body	Park Assist Module																																								
C	2010	Yukon	Body	Passenger Door Switch																																								
C	2010	Yukon	Body	Passenger Presence System																																								
C	2010	Yukon	Body	Radio																																								
C	2010	Yukon	Body	Rear Heated Seat Module																																								
C	2010	Yukon	Body	Rear HVAC/RSA																																								
C	2010	Yukon	Body	Right Side Object Detection Module																																								
C	2010	Yukon	Body	Supplemental Inflatable Restraint																																								
C	2010	Yukon	Body	Theft Deterrent Module																																								
C	2010	Yukon Hybrid	Powertrain	Engine Control Module																																								
C	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																								
C	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																								
C	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																								
C	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																								
C	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																								
C	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																								
C	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																								
C	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																								
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																								
C	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																								
C	2010	Yukon Hybrid	Body	Amplifier (Bose)																																								
C	2010	Yukon Hybrid	Body	Body Control Module																																								
C	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																								
C	2010	Yukon Hybrid	Body	Digital Radio Receiver																																								
C	2010	Yukon Hybrid	Body	Driver Door Switch																																								
C	2010	Yukon Hybrid	Body	Heated Seat Module																																								
C	2010	Yukon Hybrid	Body	HVAC Control Module																																								
C	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																								
C	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																								
C	2010	Yukon Hybrid	Body	Lift Gate Module																																								
C	2010	Yukon Hybrid	Body	Park Assist Module																																								
C	2010	Yukon Hybrid	Body	Passenger Door Switch																																								
C	2010	Yukon Hybrid	Body	Passenger Presence System																																								
C	2010	Yukon Hybrid	Body	Radio																																								
C	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																								
C	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																								
C	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																								
C	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																								
C	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
C	2010	Yukon Hybrid	Body	Theft Deterrent Module																																								
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
C	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
C	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
C	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
C	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
C	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
C	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																								
C	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																								
C	2010	Yukon XL	Chassis	Electronic Suspension Control																																								
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																								
C	2010	Yukon XL	Chassis	Trailer Brake Control Module																																								
C	2010	Yukon XL	Body	Amplifier (Bose)																																								
C	2010	Yukon XL	Body	Assist Step Controller																																								
C	2010	Yukon XL	Body	Body Control Module																																								
C	2010	Yukon XL	Body	Body Control Module (aux.)																																								
C	2010	Yukon XL	Body	Digital Radio Receiver																																								
C	2010	Yukon XL	Body	Driver Door Switch																																								
C	2010	Yukon XL	Body	HVAC Control Module Auto																																								
C	2010	Yukon XL	Body	HVAC Control Module Manual																																								
C	2010	Yukon XL	Body	Instrument Panel Cluster																																								
C	2010	Yukon XL	Body	Left Side Object Detection Module																																								
C	2010	Yukon XL	Body	Lift Gate Module																																								
C	2010	Yukon XL	Body	Memory Seat Module																																								
C	2010	Yukon XL	Body	Park Assist Module																																								
C	2010	Yukon XL	Body	Passenger Door Switch																																								
C	2010	Yukon XL	Body	Passenger Presence System																																								
C	2010	Yukon XL	Body	Radio																																								
C	2010	Yukon XL	Body	Rear Heated Seat Module																																								
C	2010	Yukon XL	Body	Rear HVAC/RSA																																								
C	2010	Yukon XL	Body	Right Side Object Detection Module																																								
C	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																								
C	2010	Yukon XL	Body	Theft Deterrent Module																																								
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																								
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																								
D	2008	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																								
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																								
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																								
D	2008	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																								
D	2008	ALL	Chassis	Electronic Brake Control Module																																								
D	2008	ALL	Body	Body Control Module																																								
D	2008	ALL	Body	Body Control Module (aux.)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
D	2008	ALL	Body	Headlamp Control Module																																								
D	2008	ALL	Body	HVAC Control Module Auto									V																															
D	2008	ALL	Body	Instrument Panel Cluster										V																														
D	2008	ALL	Body	Park Assist Module																																								
D	2008	ALL	Body	Remote Control Door Lock Receiver																																								
D	2008	ALL	Body	Supplemental Inflatable Restraint																																								
D	2008	ALL	Body	Theft Deterrent Module																																								
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																								
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																								
D	2009	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																								
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																								
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																								
D	2009	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																								
D	2009	ALL	Chassis	Electronic Brake Control Module																																								
D	2009	ALL	Body	Body Control Module																																								
D	2009	ALL	Body	Body Control Module (aux.)																																								
D	2009	ALL	Body	Headlamp Control Module																																								
D	2009	ALL	Body	HVAC Control Module Auto									V																															
D	2009	ALL	Body	Instrument Panel Cluster										V																														
D	2009	ALL	Body	Park Assist Module																																								
D	2009	ALL	Body	Remote Control Door Lock Receiver																																								
D	2009	ALL	Body	Supplemental Inflatable Restraint																																								
D	2009	ALL	Body	Theft Deterrent Module																																								
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Engine Control Module																																								
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Transmission Control Module																																								
D	2010	ALL	Powertrain	(F)2.4L L4 LD9 Rear Drive System																																								
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Engine Control Module																																								
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Transmission Control Module																																								
D	2010	ALL	Powertrain	(1)2.4L L4 LE5 Rear Drive System																																								
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Engine Control Module																																								
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Transmission Control Module																																								
D	2010	ALL	Powertrain	(G)3.2L V6 LU1 Rear Drive System																																								
D	2010	ALL	Chassis	Electronic Brake Control Module																																								
D	2010	ALL	Body	Body Control Module																																								
D	2010	ALL	Body	Body Control Module (aux.)																																								
D	2010	ALL	Body	Headlamp Control Module																																								
D	2010	ALL	Body	HVAC Control Module Auto									V																															
D	2010	ALL	Body	Instrument Panel Cluster										V																														
D	2010	ALL	Body	Park Assist Module																																								
D	2010	ALL	Body	Remote Control Door Lock Receiver																																								
D	2010	ALL	Body	Supplemental Inflatable Restraint																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2004	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
G	2004	Express/Savana	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
G	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2004	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2004	Express/Savana	Chassis	Anti-lock Brake System																																								
G	2004	Express/Savana	Chassis	VSES																																								
G	2004	Express/Savana	Body	Body Control Module																																								
G	2004	Express/Savana	Body	Instrument Panel Cluster																																								
G	2004	Express/Savana	Body	Multifunction Alarm Module																																								
G	2004	Express/Savana	Body	OnStar																																								
G	2004	Express/Savana	Body	Base Radio																																								
G	2004	Express/Savana	Body	Uplevel Radio																																								
G	2004	Express/Savana	Body	Remote Function Actuation																																								
G	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2004	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
G	2004	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
G	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2004	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																								
G	2004	Express Access/Savana Pro	Chassis	VSES																																								
G	2004	Express Access/Savana Pro	Body	Body Control Module																																								
G	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
G	2004	Express Access/Savana Pro	Body	OnStar																																								
G	2004	Express Access/Savana Pro	Body	Base Radio																																								
G	2004	Express Access/Savana Pro	Body	Uplevel Radio																																								
G	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																								
G	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2005	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Engine Control Module																																								
G	2005	Express/Savana	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2005	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2005	Express/Savana	Chassis	Anti-lock Brake System																																								
G	2005	Express/Savana	Chassis	VSES																																								
G	2005	Express/Savana	Body	Body Control Module																																								
G	2005	Express/Savana	Body	Instrument Panel Cluster																																								
G	2005	Express/Savana	Body	Multifunction Alarm Module																																								
G	2005	Express/Savana	Body	Base Radio																																								
G	2005	Express/Savana	Body	Uplevel Radio																																								
G	2005	Express/Savana	Body	Remote Function Actuation																																								
G	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																								
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2005	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Engine Control Module																																								
G	2005	Express Access/Savana Pro	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																								
G	2005	Express Access/Savana Pro	Chassis	VSES																																								
G	2005	Express Access/Savana Pro	Body	Body Control Module																																								
G	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
G	2005	Express Access/Savana Pro	Body	Base Radio																																								
G	2005	Express Access/Savana Pro	Body	Uplevel Radio																																								
G	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																								
G	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																								
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2006	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																								
G	2006	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								
G	2006	Express/Savana	Chassis	Anti-lock Brake System																																								
G	2006	Express/Savana	Chassis	VSES																																								
G	2006	Express/Savana	Body	Body Control Module																																								
G	2006	Express/Savana	Body	Instrument Panel Cluster																																								
G	2006	Express/Savana	Body	Multifunction Alarm Module																																								
G	2006	Express/Savana	Body	Passenger Presence System																																								
G	2006	Express/Savana	Body	Base Radio																																								
G	2006	Express/Savana	Body	Uplevel Radio																																								
G	2006	Express/Savana	Body	Remote Function Actuation																																								
G	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																								
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2006	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																								
G	2006	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								
G	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																								
G	2006	Express Access/Savana Pro	Chassis	VSES																																								
G	2006	Express Access/Savana Pro	Body	Body Control Module																																								
G	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
G	2006	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2006	Express Access/Savana Pro	Body	Base Radio																																								
G	2006	Express Access/Savana Pro	Body	Uplevel Radio																																								
G	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																								
G	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																								
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2007	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2007	Express/Savana	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
G	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																								
G	2007	Express/Savana	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																								
G	2007	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
G	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
G	2007	Express/Savana	Body	Body Control Module																																								
G	2007	Express/Savana	Body	Instrument Panel Cluster																																								
G	2007	Express/Savana	Body	Multifunction Alarm Module																																								
G	2007	Express/Savana	Body	Passenger Presence System																																								
G	2007	Express/Savana	Body	Base Radio																																								
G	2007	Express/Savana	Body	Uplevel Radio																																								
G	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																								
G	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM Without Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM Without Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 ECM With Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(V)4.8L V8 LR4 TCM With Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM Without Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM Without Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 ECM With Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(U)6.0L V8 LQ4 TCM With Throttle-actuated Control																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Auxiliary Heater Data Display																																								
G	2007	Express Access/Savana Pro	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Data Display																																								
G	2007	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Data Display																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
G	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
G	2007	Express Access/Savana Pro	Body	Body Control Module																																								
G	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
G	2007	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2007	Express Access/Savana Pro	Body	Radio																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
G	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
G	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
G	2008	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
G	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
G	2008	Express/Savana	Body	Body Control Module																																								
G	2008	Express/Savana	Body	Instrument Panel Cluster																																								
G	2008	Express/Savana	Body	Passenger Presence System																																								
G	2008	Express/Savana	Body	Radio																																								
G	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																								
G	2008	Express/Savana	Body	Rollover Sensor																																								
G	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2008	Express/Savana	Body	Theft Deterrent Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
G	2008	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
G	2008	Express Access/Savana Pro	Body	Body Control Module																																								
G	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2008	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2008	Express Access/Savana Pro	Body	Radio																																								
G	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2008	Express Access/Savana Pro	Body	Rollover Sensor																																								
G	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
G	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
G	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																								
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
G	2009	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
G	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
G	2009	Express/Savana	Body	Body Control Module																																								
G	2009	Express/Savana	Body	Instrument Panel Cluster																																								
G	2009	Express/Savana	Body	Passenger Presence System																																								
G	2009	Express/Savana	Body	Radio																																								
G	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																								
G	2009	Express/Savana	Body	Rollover Sensor																																								
G	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2009	Express/Savana	Body	Theft Deterrent Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
G	2009	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
G	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
G	2009	Express Access/Savana Pro	Body	Body Control Module																																								
G	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2009	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2009	Express Access/Savana Pro	Body	Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2009	Express Access/Savana Pro	Body	Rollover Sensor																																								
G	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
G	2010	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
G	2010	Express/Savana	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
G	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
G	2010	Express/Savana	Body	Body Control Module																																								
G	2010	Express/Savana	Body	Instrument Panel Cluster																																								
G	2010	Express/Savana	Body	Passenger Presence System																																								
G	2010	Express/Savana	Body	Radio																																								
G	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																								
G	2010	Express/Savana	Body	Rollover Sensor																																								
G	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																								
G	2010	Express/Savana	Body	Theft Deterrent Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Auxiliary Heater Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
G	2010	Express Access/Savana Pro	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
G	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
G	2010	Express Access/Savana Pro	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
G	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
G	2010	Express Access/Savana Pro	Body	Passenger Presence System																																								
G	2010	Express Access/Savana Pro	Body	Radio																																								
G	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
G	2010	Express Access/Savana Pro	Body	Rollover Sensor																																								
G	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
G	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
H	2004	Express/Savana	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
H	2004	Express/Savana	Chassis	Anti-lock Brake System																																								
H	2004	Express/Savana	Chassis	VSES																																								
H	2004	Express/Savana	Body	Body Control Module																																								
H	2004	Express/Savana	Body	Instrument Panel Cluster																																								
H	2004	Express/Savana	Body	Multifunction Alarm Module																																								
H	2004	Express/Savana	Body	OnStar																																								
H	2004	Express/Savana	Body	Base Radio																																								
H	2004	Express/Savana	Body	Uplevel Radio																																								
H	2004	Express/Savana	Body	Remote Function Actuation																																								
H	2004	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
H	2004	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
H	2004	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																								
H	2004	Express Access/Savana Pro	Chassis	VSES																																								
H	2004	Express Access/Savana Pro	Body	Body Control Module																																								
H	2004	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2004	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
H	2004	Express Access/Savana Pro	Body	OnStar																																								
H	2004	Express Access/Savana Pro	Body	Base Radio																																								
H	2004	Express Access/Savana Pro	Body	Uplevel Radio																																								
H	2004	Express Access/Savana Pro	Body	Remote Function Actuation																																								
H	2004	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
H	2005	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
H	2005	Express/Savana	Chassis	Anti-lock Brake System																																								
H	2005	Express/Savana	Chassis	VSES																																								
H	2005	Express/Savana	Body	Body Control Module																																								
H	2005	Express/Savana	Body	Instrument Panel Cluster																																								
H	2005	Express/Savana	Body	Multifunction Alarm Module																																								
H	2005	Express/Savana	Body	Base Radio																																								
H	2005	Express/Savana	Body	Uplevel Radio																																								
H	2005	Express/Savana	Body	Remote Function Actuation																																								
H	2005	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2005	Express/Savana	Body	Vehicle Comm. Interface Module																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
H	2005	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
H	2005	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																								
H	2005	Express Access/Savana Pro	Chassis	VSES																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2005	Express Access/Savana Pro	Body	Body Control Module																																								
H	2005	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2005	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
H	2005	Express Access/Savana Pro	Body	Base Radio																																								
H	2005	Express Access/Savana Pro	Body	Uplevel Radio																																								
H	2005	Express Access/Savana Pro	Body	Remote Function Actuation																																								
H	2005	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2005	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
H	2006	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
H	2006	Express/Savana	Chassis	Anti-lock Brake System																																								
H	2006	Express/Savana	Chassis	VSES																																								
H	2006	Express/Savana	Body	Body Control Module																																								
H	2006	Express/Savana	Body	Instrument Panel Cluster																																								
H	2006	Express/Savana	Body	Multifunction Alarm Module																																								
H	2006	Express/Savana	Body	Passenger Presence System																																								
H	2006	Express/Savana	Body	Base Radio																																								
H	2006	Express/Savana	Body	Uplevel Radio																																								
H	2006	Express/Savana	Body	Remote Function Actuation																																								
H	2006	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2006	Express/Savana	Body	Vehicle Comm. Interface Module																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
H	2006	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
H	2006	Express Access/Savana Pro	Chassis	Anti-lock Brake System																																								
H	2006	Express Access/Savana Pro	Chassis	VSES																																								
H	2006	Express Access/Savana Pro	Body	Body Control Module																																								
H	2006	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2006	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
H	2006	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2006	Express Access/Savana Pro	Body	Base Radio																																								
H	2006	Express Access/Savana Pro	Body	Uplevel Radio																																								
H	2006	Express Access/Savana Pro	Body	Remote Function Actuation																																								
H	2006	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2006	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																								
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
H	2007	Express/Savana	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
H	2007	Express/Savana	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
H	2007	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
H	2007	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
H	2007	Express/Savana	Body	Body Control Module																																								
H	2007	Express/Savana	Body	Instrument Panel Cluster																																								
H	2007	Express/Savana	Body	Multifunction Alarm Module																																								
H	2007	Express/Savana	Body	Passenger Presence System																																								
H	2007	Express/Savana	Body	Base Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2007	Express/Savana	Body	Uplevel Radio																																								
H	2007	Express/Savana	Body	Remote Control Door Lock Receiver																																								
H	2007	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2007	Express/Savana	Body	Vehicle Comm. Interface Module																																								
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
H	2007	Express Access/Savana Pro	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM Without Throttle-actuated Control																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM Without Throttle-actuated Control																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 ECM With Throttle-actuated Control																																								
H	2007	Express Access/Savana Pro	Powertrain	(T)5.3L V8 LM7 TCM With Throttle-actuated Control																																								
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
H	2007	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
H	2007	Express Access/Savana Pro	Body	Body Control Module																																								
H	2007	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2007	Express Access/Savana Pro	Body	Multifunction Alarm Module																																								
H	2007	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2007	Express Access/Savana Pro	Body	Base Radio																																								
H	2007	Express Access/Savana Pro	Body	Uplevel Radio																																								
H	2007	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
H	2007	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2007	Express Access/Savana Pro	Body	Vehicle Comm. Interface Module																																								
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
H	2008	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
H	2008	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2008	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
H	2008	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
H	2008	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
H	2008	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
H	2008	Express/Savana	Body	Body Control Module																																								
H	2008	Express/Savana	Body	Instrument Panel Cluster																																								
H	2008	Express/Savana	Body	Passenger Presence System																																								
H	2008	Express/Savana	Body	Radio																																								
H	2008	Express/Savana	Body	Remote Control Door Lock Receiver																																								
H	2008	Express/Savana	Body	Rollover Sensor																																								
H	2008	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2008	Express/Savana	Body	Theft Deterrent Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
H	2008	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
H	2008	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2008	Express Access/Savana Pro	Body	Body Control Module																																								
H	2008	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2008	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2008	Express Access/Savana Pro	Body	Radio																																								
H	2008	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
H	2008	Express Access/Savana Pro	Body	Rollover Sensor																																								
H	2008	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2008	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
H	2009	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
H	2009	Express/Savana	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2009	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
H	2009	Express/Savana	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
H	2009	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
H	2009	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
H	2009	Express/Savana	Body	Body Control Module																																								
H	2009	Express/Savana	Body	Instrument Panel Cluster																																								
H	2009	Express/Savana	Body	Passenger Presence System																																								
H	2009	Express/Savana	Body	Radio																																								
H	2009	Express/Savana	Body	Remote Control Door Lock Receiver																																								
H	2009	Express/Savana	Body	Rollover Sensor																																								
H	2009	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2009	Express/Savana	Body	Theft Deterrent Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
H	2009	Express Access/Savana Pro	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
H	2009	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
H	2009	Express Access/Savana Pro	Body	Body Control Module																																								
H	2009	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2009	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2009	Express Access/Savana Pro	Body	Radio																																								
H	2009	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
H	2009	Express Access/Savana Pro	Body	Rollover Sensor																																								
H	2009	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2009	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
H	2010	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2010	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
H	2010	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
H	2010	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
H	2010	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
H	2010	Express/Savana	Body	Body Control Module																																								
H	2010	Express/Savana	Body	Instrument Panel Cluster																																								
H	2010	Express/Savana	Body	Passenger Presence System																																								
H	2010	Express/Savana	Body	Radio																																								
H	2010	Express/Savana	Body	Remote Control Door Lock Receiver																																								
H	2010	Express/Savana	Body	Rollover Sensor																																								
H	2010	Express/Savana	Body	Supplemental Inflatable Restraint																																								
H	2010	Express/Savana	Body	Theft Deterrent Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
H	2010	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
H	2010	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
H	2010	Express Access/Savana Pro	Body	Body Control Module																																								
H	2010	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
H	2010	Express Access/Savana Pro	Body	Passenger Presence System																																								
H	2010	Express Access/Savana Pro	Body	Radio																																								
H	2010	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
H	2010	Express Access/Savana Pro	Body	Rollover Sensor																																								
H	2010	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
H	2010	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2004	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
K	2004	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																								
K	2004	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																								
K	2004	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																								
K	2004	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																								
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
K	2004	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Engine Control Module																																								
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Transmission Control Module																																								
K	2004	ALL	Powertrain	(1)6.6L V8 LB7 Diesel Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
K	2004	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																								
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																								
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																								
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																								
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																								
K	2004	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																								
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW																																								
K	2004	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
K	2004	ALL	Chassis	ABS Over 8600 GVW																																								
K	2004	ALL	Chassis	EHPS (Parallel Hybrid)																																								
K	2004	ALL	Chassis	ESC																																								
K	2004	ALL	Chassis	Rear Wheel Steering																																								
K	2004	ALL	Chassis	Tire Pressure Monitor																																								
K	2004	ALL	Chassis	Traction Assist (If Equipped)																																								
K	2004	ALL	Chassis	VSES																																								
K	2004	ALL	Body	Amplifier (Bose)																																								
K	2004	ALL	Body	Body Control Module																																								
K	2004	ALL	Body	CD Changer																																								
K	2004	ALL	Body	Chime																																								
K	2004	ALL	Body	Driver Door Module																																								
K	2004	ALL	Body	Driver Seat Module																																								
K	2004	ALL	Body	Heating and Air Conditioning Auto																																								
K	2004	ALL	Body	Heating and Air Conditioning Manual																																								
K	2004	ALL	Body	Heating and Air Conditioning Auto PHT																																								
K	2004	ALL	Body	Instrument Panel Cluster																																								
K	2004	ALL	Body	OnStar																																								
K	2004	ALL	Body	Passenger Door Module																																								
K	2004	ALL	Body	Passenger Presence System																																								
K	2004	ALL	Body	Radio Base																																								
K	2004	ALL	Body	Radio Uplevel																																								
K	2004	ALL	Body	Radio Navigation																																								
K	2004	ALL	Body	Rear Aux. Climate Module																																								
K	2004	ALL	Body	Rear HVAC																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2004	ALL	Body	Rear Seat Audio																																								
K	2004	ALL	Body	Rear Seat Entertainment																																								
K	2004	ALL	Body	Supplemental Inflatable Restraint																																								
K	2004	ALL	Body	Vehicle Theft Deterrent																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																								
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2005	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																								
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
K	2005	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																								
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																								
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																								
K	2005	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																								
K	2005	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																								
K	2005	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																								
K	2005	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																								
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
K	2005	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
K	2005	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 5 Speed																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																								
K	2005	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																								
K	2005	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2005	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																								
K	2005	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
K	2005	ALL	Chassis	ABS Over 8600 GVW																																								
K	2005	ALL	Chassis	EHPS (Parallel Hybrid)																																								
K	2005	ALL	Chassis	ESC																																								
K	2005	ALL	Chassis	Rear Wheel Steering																																								
K	2005	ALL	Chassis	Tire Pressure Monitor																																								
K	2005	ALL	Chassis	Traction Assist (If Equipped)																																								
K	2005	ALL	Chassis	VSES																																								
K	2005	ALL	Body	Amplifier (Bose)																																								
K	2005	ALL	Body	Body Control Module																																								
K	2005	ALL	Body	CD Changer																																								
K	2005	ALL	Body	Chime																																								
K	2005	ALL	Body	Disc Player and Video Display																																								
K	2005	ALL	Body	Driver Door Module																																								
K	2005	ALL	Body	Driver Seat Module																																								
K	2005	ALL	Body	Generator Battery Control Module																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto																																								
K	2005	ALL	Body	Heating and Air Conditioning Auto PHT																																								
K	2005	ALL	Body	Heating and Air Conditioning Manual																																								
K	2005	ALL	Body	Instrument Panel Cluster																																								
K	2005	ALL	Body	Passenger Door Module																																								
K	2005	ALL	Body	Passenger Presence System																																								
K	2005	ALL	Body	Base Radio																																								
K	2005	ALL	Body	Uplevel Radio																																								
K	2005	ALL	Body	Navigation Radio																																								
K	2005	ALL	Body	Rear Aux. Climate Module																																								
K	2005	ALL	Body	Rear HVAC																																								
K	2005	ALL	Body	Rear Seat Audio																																								
K	2005	ALL	Body	Supplemental Inflatable Restraint																																								
K	2005	ALL	Body	Vehicle Comm. Interface Module																																								
K	2005	ALL	Body	Vehicle Theft Deterrent																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ECM																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid HPCM																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid BECM																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid SGCM																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid TCM																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Alternative Fuels Parallel Hybrid ATC																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ECM																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG TCM																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel ECM																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Bi-Fuel TCM																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Alternative Fuels Dedicated CNG ATC																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2006	ALL	Powertrain	(X)4.3L V6 LU3 Automatic Transfer Case																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Engine Control Module																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Transmission Control Module																																								
K	2006	ALL	Powertrain	(V)4.8L V8 LR4 Automatic Transfer Case																																								
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Engine Control Module																																								
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2006	ALL	Powertrain	(B)5.3L V8 L33 Automatic Transfer Case																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Engine Control Module																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Transmission Control Module																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case 4 Button Selectable																																								
K	2006	ALL	Powertrain	(Z)5.3L V8 L59 Automatic Transfer Case With Traction Control																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Engine Control Module																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Transmission Control Module																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 3 Button Selectable																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case 4 Button Selectable																																								
K	2006	ALL	Powertrain	(T)5.3L V8 LM7 Automatic Transfer Case With Traction Control																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Engine Control Module																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Under 8600																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Transmission Control Module Equal or Over 8600																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 3 Button Selectable																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case 4 Button Selectable																																								
K	2006	ALL	Powertrain	(U)6.0L V8 LQ4 Automatic Transfer Case With Traction Control																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Engine Control Module																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Transmission Control Module																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 3 Button Selectable																																								
K	2006	ALL	Powertrain	(N)6.0L V8 LQ9 Automatic Transfer Case 4 Button Selectable																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Engine Control Module																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Transmission Control Module																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Diesel Glow Plug Data Display																																								
K	2006	ALL	Powertrain	(D)6.6L V8 LBZ Automatic Transfer Case																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Engine Control Module																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Transmission Control Module																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Glow Plug Data Display																																								
K	2006	ALL	Powertrain	(2)6.6L V8 LLY Diesel Automatic Transfer Case																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Engine Control Module																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 6 Speed																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Transmission Control Module 4 Speed																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 3 Button Selectable																																								
K	2006	ALL	Powertrain	(G)8.1L V8 L18 Automatic Transfer Case 4 Button Selectable																																								
K	2006	ALL	Chassis	ABS Rear Drum Brakes Equal to or Under 8600 GVW																																								
K	2006	ALL	Chassis	ABS Rear Disc Brakes Equal to or Under 8600 GVW																																								
K	2006	ALL	Chassis	ABS Equal to or Under 8600 GVW PHT																																								
K	2006	ALL	Chassis	ABS Over 8600 GVW																																								
K	2006	ALL	Chassis	EHPS (Parallel Hybrid)																																								
K	2006	ALL	Chassis	ESC																																								
K	2006	ALL	Chassis	Tire Pressure Monitor																																								
K	2006	ALL	Chassis	Traction Assist (If Equipped)																																								
K	2006	ALL	Chassis	VSES																																								
K	2006	ALL	Body	Amplifier (Bose)																																								
K	2006	ALL	Body	Body Control Module																																								
K	2006	ALL	Body	CD Changer																																								
K	2006	ALL	Body	Chime																																								
K	2006	ALL	Body	Disc Player and Video Display																																								
K	2006	ALL	Body	Driver Door Module																																								
K	2006	ALL	Body	Driver Seat Module																																								
K	2006	ALL	Body	Generator Battery Control Module																																								
K	2006	ALL	Body	Heating and Air Conditioning Auto																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2006	ALL	Body	Heating and Air Conditioning Auto PHT																																								
K	2006	ALL	Body	Heating and Air Conditioning Manual																																								
K	2006	ALL	Body	Instrument Panel Cluster																																								
K	2006	ALL	Body	Passenger Door Module																																								
K	2006	ALL	Body	Passenger Presence System																																								
K	2006	ALL	Body	Base Radio																																								
K	2006	ALL	Body	Uplevel Radio																																								
K	2006	ALL	Body	Navigation Radio																																								
K	2006	ALL	Body	Rear Aux. Climate Module																																								
K	2006	ALL	Body	Rear HVAC																																								
K	2006	ALL	Body	Rear Seat Audio																																								
K	2006	ALL	Body	Supplemental Inflatable Restraint																																								
K	2006	ALL	Body	Vehicle Theft Deterrent																																								
K	2006	ALL	Body	Vehicle Comm. Interface Module																																								
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2007	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2007	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
K	2007	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																								
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2007	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2007	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
K	2007	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																								
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																								
K	2007	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
K	2007	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2007	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2007	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2007	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2007	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2007	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2007	Sierra	Chassis	Electronic Suspension Control																																								
K	2007	Sierra	Chassis	Trailer Brake Control Module																																								
K	2007	Sierra	Body	Amplifier (Bose)																																								
K	2007	Sierra	Body	Body Control Module																																								
K	2007	Sierra	Body	Body Control Module (aux.)																																								
K	2007	Sierra	Body	Digital Radio Receiver																																								
K	2007	Sierra	Body	Driver Door Switch																																								
K	2007	Sierra	Body	HVAC Control Module Auto																																								
K	2007	Sierra	Body	HVAC Control Module Manual																																								
K	2007	Sierra	Body	Instrument Panel Cluster																																								
K	2007	Sierra	Body	Memory Seat Module																																								
K	2007	Sierra	Body	Park Assist Module																																								
K	2007	Sierra	Body	Passenger Door Switch																																								
K	2007	Sierra	Body	Passenger Presence System																																								
K	2007	Sierra	Body	Radio																																								
K	2007	Sierra	Body	Rear Heated Seat Module																																								
K	2007	Sierra	Body	Rear HVAC/RSA																																								
K	2007	Sierra	Body	Rollover Sensor																																								
K	2007	Sierra	Body	Supplemental Inflatable Restraint																																								
K	2007	Sierra	Body	Theft Deterrent Module																																								
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2007	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
K	2007	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																								
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
K	2007	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2007	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2007	Yukon	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2007	Yukon	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2007	Yukon	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2007	Yukon	Chassis	Electronic Suspension Control																																								
K	2007	Yukon	Chassis	Trailer Brake Control Module																																								
K	2007	Yukon	Body	Amplifier (Bose)																																								
K	2007	Yukon	Body	Assist Step Controller																																								
K	2007	Yukon	Body	Body Control Module																																								
K	2007	Yukon	Body	Body Control Module (aux.)																																								
K	2007	Yukon	Body	Digital Radio Receiver																																								
K	2007	Yukon	Body	Driver Door Switch																																								
K	2007	Yukon	Body	HVAC Control Module Auto																																								
K	2007	Yukon	Body	HVAC Control Module Manual																																								
K	2007	Yukon	Body	Instrument Panel Cluster																																								
K	2007	Yukon	Body	Lift Gate Module																																								
K	2007	Yukon	Body	Memory Seat Module																																								
K	2007	Yukon	Body	Park Assist Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2007	Yukon	Body	Passenger Door Switch																																								
K	2007	Yukon	Body	Passenger Presence System																																								
K	2007	Yukon	Body	Radio																																								
K	2007	Yukon	Body	Rear Heated Seat Module																																								
K	2007	Yukon	Body	Rear HVAC/RSA																																								
K	2007	Yukon	Body	Rollover Sensor																																								
K	2007	Yukon	Body	Supplemental Inflatable Restraint																																								
K	2007	Yukon	Body	Theft Deterrent Module																																								
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2007	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2007	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2007	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
K	2007	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2007	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2007	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2007	Yukon XL	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2007	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2007	Yukon XL	Chassis	Electronic Suspension Control																																								
K	2007	Yukon XL	Chassis	Trailer Brake Control Module																																								
K	2007	Yukon XL	Body	Amplifier (Bose)																																								
K	2007	Yukon XL	Body	Assist Step Controller																																								
K	2007	Yukon XL	Body	Body Control Module																																								
K	2007	Yukon XL	Body	Body Control Module (aux.)																																								
K	2007	Yukon XL	Body	Digital Radio Receiver																																								
K	2007	Yukon XL	Body	Driver Door Switch																																								
K	2007	Yukon XL	Body	HVAC Control Module Auto																																								
K	2007	Yukon XL	Body	HVAC Control Module Manual																																								
K	2007	Yukon XL	Body	Instrument Panel Cluster																																								
K	2007	Yukon XL	Body	Lift Gate Module																																								
K	2007	Yukon XL	Body	Memory Seat Module																																								
K	2007	Yukon XL	Body	Park Assist Module																																								
K	2007	Yukon XL	Body	Passenger Door Switch																																								
K	2007	Yukon XL	Body	Passenger Presence System																																								
K	2007	Yukon XL	Body	Radio																																								
K	2007	Yukon XL	Body	Rear Heated Seat Module																																								
K	2007	Yukon XL	Body	Rear HVAC/RSA																																								
K	2007	Yukon XL	Body	Rollover Sensor																																								
K	2007	Yukon XL	Body	Supplemental Inflatable Restraint																																								
K	2007	Yukon XL	Body	Theft Deterrent Module																																								
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2008	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2008	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
K	2008	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																								
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2008	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2008	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
K	2008	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																								
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																								
K	2008	Sierra	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																								
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
K	2008	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2008	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2008	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2008	Sierra	Chassis	EBCM Under 8600 GVW With VSES																																								
K	2008	Sierra	Chassis	EBCM Under 8600 GVW Without VSES																																								
K	2008	Sierra	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2008	Sierra	Chassis	Electronic Suspension Control																																								
K	2008	Sierra	Chassis	Trailer Brake Control Module																																								
K	2008	Sierra	Body	Amplifier (Bose)																																								
K	2008	Sierra	Body	Body Control Module																																								
K	2008	Sierra	Body	Body Control Module (aux.)																																								
K	2008	Sierra	Body	Digital Radio Receiver																																								
K	2008	Sierra	Body	Driver Door Switch																																								
K	2008	Sierra	Body	HVAC Control Module Auto																																								
K	2008	Sierra	Body	HVAC Control Module Manual																																								
K	2008	Sierra	Body	Instrument Panel Cluster																																								
K	2008	Sierra	Body	Memory Seat Module																																								
K	2008	Sierra	Body	Park Assist Module																																								
K	2008	Sierra	Body	Passenger Door Switch																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2008	Sierra	Body	Passenger Presence System																																								
K	2008	Sierra	Body	Radio																																								
K	2008	Sierra	Body	Rear Heated Seat Module																																								
K	2008	Sierra	Body	Rear HVAC/RSA																																								
K	2008	Sierra	Body	Rollover Sensor																																								
K	2008	Sierra	Body	Supplemental Inflatable Restraint																																								
K	2008	Sierra	Body	Remote Control Door Lock Receiver											V	V	V																											
K	2008	Sierra	Body	Theft Deterrent Module																																								
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2008	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
K	2008	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																								
K	2008	Yukon	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2008	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2008	Yukon	Chassis	Electronic Brake Control Module																																								
K	2008	Yukon	Chassis	Electronic Suspension Control																																								
K	2008	Yukon	Chassis	Trailer Brake Control Module																																								
K	2008	Yukon	Body	Amplifier (Bose)																																								
K	2008	Yukon	Body	Assist Step Controller																																								
K	2008	Yukon	Body	Body Control Module																																								
K	2008	Yukon	Body	Body Control Module (aux.)																																								
K	2008	Yukon	Body	Digital Radio Receiver																																								
K	2008	Yukon	Body	Driver Door Switch																																								
K	2008	Yukon	Body	HVAC Control Module Auto																																								
K	2008	Yukon	Body	HVAC Control Module Manual																																								
K	2008	Yukon	Body	Instrument Panel Cluster																																								
K	2008	Yukon	Body	Lift Gate Module																																								
K	2008	Yukon	Body	Memory Seat Module																																								
K	2008	Yukon	Body	Park Assist Module																																								
K	2008	Yukon	Body	Passenger Door Switch																																								
K	2008	Yukon	Body	Passenger Presence System																																								
K	2008	Yukon	Body	Radio																																								
K	2008	Yukon	Body	Rear Heated Seat Module																																								
K	2008	Yukon	Body	Rear HVAC/RSA																																								
K	2008	Yukon	Body	Rollover Sensor																																								
K	2008	Yukon	Body	Supplemental Inflatable Restraint																																								
K	2008	Yukon	Body	Theft Deterrent Module																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2008	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2008	Yukon Hybrid	Chassis	Electronic Brake Control Module																																								
K	2008	Yukon Hybrid	Chassis	Electronic Suspension Control																																								
K	2008	Yukon Hybrid	Chassis	Power Steering Control Module																																								
K	2008	Yukon Hybrid	Chassis	Trailer Brake Control Module																																								
K	2008	Yukon Hybrid	Body	A/C Compressor Control Module																																								
K	2008	Yukon Hybrid	Body	Amplifier (Bose)																																								
K	2008	Yukon Hybrid	Body	Body Control Module																																								
K	2008	Yukon Hybrid	Body	Body Control Module (aux.)																																								
K	2008	Yukon Hybrid	Body	Digital Radio Receiver																																								
K	2008	Yukon Hybrid	Body	Driver Door Switch																																								
K	2008	Yukon Hybrid	Body	HVAC Control Module																																								
K	2008	Yukon Hybrid	Body	Instrument Panel Cluster																																								
K	2008	Yukon Hybrid	Body	Lift Gate Module																																								
K	2008	Yukon Hybrid	Body	Memory Seat Module																																								
K	2008	Yukon Hybrid	Body	Park Assist Module																																								
K	2008	Yukon Hybrid	Body	Passenger Door Switch																																								
K	2008	Yukon Hybrid	Body	Passenger Presence System																																								
K	2008	Yukon Hybrid	Body	Radio																																								
K	2008	Yukon Hybrid	Body	Rear Heated Seat Module																																								
K	2008	Yukon Hybrid	Body	Rear HVAC/RSA																																								
K	2008	Yukon Hybrid	Body	Rollover Sensor																																								
K	2008	Yukon Hybrid	Body	Serial Data Gateway Module																																								
K	2008	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2008	Yukon Hybrid	Body	Theft Deterrent Module																																								
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2008	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2008	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2008	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Engine Control Module																																								
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Fuel Pump Control Module																																								
K	2008	Yukon XL	Powertrain	(8)6.2L V8 L92 Transmission Control Module																																								
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2008	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2008	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2008	Yukon XL	Chassis	EBCM Under 8600 GVW																																								
K	2008	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2008	Yukon XL	Chassis	Electronic Suspension Control																																								
K	2008	Yukon XL	Chassis	Trailer Brake Control Module																																								
K	2008	Yukon XL	Body	Amplifier (Bose)																																								
K	2008	Yukon XL	Body	Assist Step Controller																																								
K	2008	Yukon XL	Body	Body Control Module																																								
K	2008	Yukon XL	Body	Body Control Module (aux.)																																								
K	2008	Yukon XL	Body	Digital Radio Receiver																																								
K	2008	Yukon XL	Body	Driver Door Switch																																								
K	2008	Yukon XL	Body	HVAC Control Module Auto																																								
K	2008	Yukon XL	Body	HVAC Control Module Manual																																								
K	2008	Yukon XL	Body	Instrument Panel Cluster																																								
K	2008	Yukon XL	Body	Lift Gate Module																																								
K	2008	Yukon XL	Body	Memory Seat Module																																								
K	2008	Yukon XL	Body	Park Assist Module																																								
K	2008	Yukon XL	Body	Passenger Door Switch																																								
K	2008	Yukon XL	Body	Passenger Presence System																																								
K	2008	Yukon XL	Body	Radio																																								
K	2008	Yukon XL	Body	Rear Heated Seat Module																																								
K	2008	Yukon XL	Body	Rear HVAC/RSA																																								
K	2008	Yukon XL	Body	Rollover Sensor																																								
K	2008	Yukon XL	Body	Supplemental Inflatable Restraint																																								
K	2008	Yukon XL	Body	Theft Deterrent Module																																								
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2009	Sierra	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
K	2009	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																								
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
K	2009	Sierra	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																								
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manaul																																								
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2009	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																								
K	2009	Sierra	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																								
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																								
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
K	2009	Sierra	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
K	2009	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2009	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2009	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																								
K	2009	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																								
K	2009	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																								
K	2009	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																								
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
K	2009	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
K	2009	Sierra	Chassis	Electronic Suspension Control																																								
K	2009	Sierra	Chassis	Trailer Brake Control Module																																								
K	2009	Sierra	Body	Amplifier (Bose)																																								
K	2009	Sierra	Body	Body Control Module																																								
K	2009	Sierra	Body	Body Control Module (aux.)																																								
K	2009	Sierra	Body	Digital Radio Receiver																																								
K	2009	Sierra	Body	Driver Door Switch																																								
K	2009	Sierra	Body	HVAC Control Module Auto																																								
K	2009	Sierra	Body	HVAC Control Module Manual																																								
K	2009	Sierra	Body	Instrument Panel Cluster																																								
K	2009	Sierra	Body	Memory Seat Module																																								
K	2009	Sierra	Body	Park Assist Module																																								
K	2009	Sierra	Body	Passenger Door Switch																																								
K	2009	Sierra	Body	Passenger Presence System																																								
K	2009	Sierra	Body	Radio																																								
K	2009	Sierra	Body	Rear Heated Seat Module																																								
K	2009	Sierra	Body	Rear HVAC/RSA																																								
K	2009	Sierra	Body	Rollover Sensor																																								
K	2009	Sierra	Body	Supplemental Inflatable Restraint																																								
K	2009	Sierra	Body	Theft Deterrent Module																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2009	Sierra Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2009	Sierra Hybrid	Chassis	Electronic Brake Control Module																																								
K	2009	Sierra Hybrid	Chassis	Electronic Suspension Control																																								
K	2009	Sierra Hybrid	Chassis	Power Steering Control Module																																								
K	2009	Sierra Hybrid	Chassis	Trailer Brake Control Module																																								
K	2009	Sierra Hybrid	Body	A/C Compressor Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2009	Sierra Hybrid	Body	Amplifier (Bose)																																								
K	2009	Sierra Hybrid	Body	Body Control Module																																								
K	2009	Sierra Hybrid	Body	Body Control Module (aux.)																																								
K	2009	Sierra Hybrid	Body	Digital Radio Receiver																																								
K	2009	Sierra Hybrid	Body	Driver Door Switch																																								
K	2009	Sierra Hybrid	Body	HVAC Control Module																																								
K	2009	Sierra Hybrid	Body	Instrument Panel Cluster																																								
K	2009	Sierra Hybrid	Body	Memory Seat Module																																								
K	2009	Sierra Hybrid	Body	Park Assist Module																																								
K	2009	Sierra Hybrid	Body	Passenger Door Switch																																								
K	2009	Sierra Hybrid	Body	Passenger Presence System																																								
K	2009	Sierra Hybrid	Body	Radio																																								
K	2009	Sierra Hybrid	Body	Rear Heated Seat Module																																								
K	2009	Sierra Hybrid	Body	Rear HVAC/RSA																																								
K	2009	Sierra Hybrid	Body	Rollover Sensor																																								
K	2009	Sierra Hybrid	Body	Serial Data Gateway Module																																								
K	2009	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2009	Sierra Hybrid	Body	Theft Deterrent Module																																								
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 6 Speed																																								
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transmission Control Module 4 Speed																																								
K	2009	Yukon	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Engine Control Module																																								
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Fuel Pump Control Module																																								
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transmission Control Module																																								
K	2009	Yukon	Powertrain	(C)4.8L V8 LY2 Transfer Case Control Module																																								
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2009	Yukon	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2009	Yukon	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 6 Speed																																								
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module 4 Speed																																								
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2009	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2009	Yukon	Chassis	Electronic Brake Control Module																																								
K	2009	Yukon	Chassis	Electronic Suspension Control																																								
K	2009	Yukon	Chassis	Trailer Brake Control Module																																								
K	2009	Yukon	Body	Amplifier (Bose)																																								
K	2009	Yukon	Body	Assist Step Controller																																								
K	2009	Yukon	Body	Body Control Module																																								
K	2009	Yukon	Body	Body Control Module (aux.)																																								
K	2009	Yukon	Body	Digital Radio Receiver																																								
K	2009	Yukon	Body	Driver Door Switch																																								
K	2009	Yukon	Body	HVAC Control Module Auto																																								
K	2009	Yukon	Body	HVAC Control Module Manual																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2009	Yukon	Body	Instrument Panel Cluster																																								
K	2009	Yukon	Body	Left Side Object Detection Module																																								
K	2009	Yukon	Body	Lift Gate Module																																								
K	2009	Yukon	Body	Memory Seat Module																																								
K	2009	Yukon	Body	Park Assist Module																																								
K	2009	Yukon	Body	Passenger Door Switch																																								
K	2009	Yukon	Body	Passenger Presence System																																								
K	2009	Yukon	Body	Radio																																								
K	2009	Yukon	Body	Rear Heated Seat Module																																								
K	2009	Yukon	Body	Rear HVAC/RSA																																								
K	2009	Yukon	Body	Right Side Object Detection Module																																								
K	2009	Yukon	Body	Rollover Sensor																																								
K	2009	Yukon	Body	Supplemental Inflatable Restraint																																								
K	2009	Yukon	Body	Theft Deterrent Module																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Engine Control Module																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Accessory Power Module																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Battery Energy Control Module																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Fuel Pump Control Module																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Hybrid Powertrain Control Module																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 1																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Motor Control Modules 2																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transmission Control Module																																								
K	2009	Yukon Hybrid	Powertrain	(5)6.0L V8 LFA Transfer Case Control Module																																								
K	2009	Yukon Hybrid	Chassis	Electronic Brake Control Module																																								
K	2009	Yukon Hybrid	Chassis	Electronic Suspension Control																																								
K	2009	Yukon Hybrid	Chassis	Power Steering Control Module																																								
K	2009	Yukon Hybrid	Chassis	Trailer Brake Control Module																																								
K	2009	Yukon Hybrid	Body	A/C Compressor Control Module																																								
K	2009	Yukon Hybrid	Body	Amplifier (Bose)																																								
K	2009	Yukon Hybrid	Body	Body Control Module																																								
K	2009	Yukon Hybrid	Body	Body Control Module (aux.)																																								
K	2009	Yukon Hybrid	Body	Digital Radio Receiver																																								
K	2009	Yukon Hybrid	Body	Driver Door Switch																																								
K	2009	Yukon Hybrid	Body	Heated Seat Module																																								
K	2009	Yukon Hybrid	Body	HVAC Control Module																																								
K	2009	Yukon Hybrid	Body	Instrument Panel Cluster																																								
K	2009	Yukon Hybrid	Body	Left Side Object Detection Module																																								
K	2009	Yukon Hybrid	Body	Park Assist Module																																								
K	2009	Yukon Hybrid	Body	Passenger Door Switch																																								
K	2009	Yukon Hybrid	Body	Passenger Presence System																																								
K	2009	Yukon Hybrid	Body	Radio																																								
K	2009	Yukon Hybrid	Body	Rear Heated Seat Module																																								
K	2009	Yukon Hybrid	Body	Rear HVAC/RSA																																								
K	2009	Yukon Hybrid	Body	Right Side Object Detection Module																																								
K	2009	Yukon Hybrid	Body	Rollover Sensor																																								
K	2009	Yukon Hybrid	Body	Serial Data Gateway Module																																								
K	2009	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2009	Yukon Hybrid	Body	Theft Deterrent Module																																								
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Engine Control Module																																								
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Fuel Pump Control Module																																								
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2009	Yukon XL	Powertrain	(Y)6.0L V8 L76 Transfer Case Control Module																																								
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Engine Control Module																																								
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2009	Yukon XL	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Engine Control Module																																								
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Fuel Pump Control Module																																								
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transmission Control Module																																								
K	2009	Yukon XL	Powertrain	(J)5.3L V8 LY5 Transfer Case Control Module																																								
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2009	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2009	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2009	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2009	Yukon XL	Chassis	EBCM Under 8600 GVW																																								
K	2009	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																								
K	2009	Yukon XL	Chassis	Electronic Suspension Control																																								
K	2009	Yukon XL	Chassis	Trailer Brake Control Module																																								
K	2009	Yukon XL	Body	Amplifier (Bose)																																								
K	2009	Yukon XL	Body	Assist Step Controller																																								
K	2009	Yukon XL	Body	Body Control Module																																								
K	2009	Yukon XL	Body	Body Control Module (aux.)																																								
K	2009	Yukon XL	Body	Digital Radio Receiver																																								
K	2009	Yukon XL	Body	Driver Door Switch																																								
K	2009	Yukon XL	Body	HVAC Control Module Auto																																								
K	2009	Yukon XL	Body	HVAC Control Module Manual																																								
K	2009	Yukon XL	Body	Instrument Panel Cluster																																								
K	2009	Yukon XL	Body	Left Side Object Detection Module																																								
K	2009	Yukon XL	Body	Lift Gate Module																																								
K	2009	Yukon XL	Body	Memory Seat Module																																								
K	2009	Yukon XL	Body	Park Assist Module																																								
K	2009	Yukon XL	Body	Passenger Door Switch																																								
K	2009	Yukon XL	Body	Passenger Presence System																																								
K	2009	Yukon XL	Body	Radio																																								
K	2009	Yukon XL	Body	Rear Heated Seat Module																																								
K	2009	Yukon XL	Body	Rear HVAC/RSA																																								
K	2009	Yukon XL	Body	Right Side Object Detection Module																																								
K	2009	Yukon XL	Body	Rollover Sensor																																								
K	2009	Yukon XL	Body	Supplemental Inflatable Restraint																																								
K	2009	Yukon XL	Body	Theft Deterrent Module																																								
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
K	2010	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Auto																																								
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Engine Control Module Manual																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transmission Control Module																																								
K	2010	Sierra	Powertrain	(K)6.0L V8 LY6 Transfer Case Control Module																																								
K	2010	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
K	2010	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																								
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Engine Control Module																																								
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Glow Plug Control Module																																								
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel PTO Control Module																																								
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transmission Control Module																																								
K	2010	Sierra	Powertrain	(6)6.6L V8 LMM Diesel Transfer Case Control Module																																								
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2010	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2010	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2010	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
K	2010	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																								
K	2010	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																								
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
K	2010	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
K	2010	Sierra	Chassis	Electronic Suspension Control																																								
K	2010	Sierra	Chassis	Trailer Brake Control Module																																								
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Sierra	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Sierra	Body	Amplifier (Bose)																																								
K	2010	Sierra	Body	Body Control Module																																								
K	2010	Sierra	Body	Body Control Module (aux.)																																								
K	2010	Sierra	Body	Digital Radio Receiver																																								
K	2010	Sierra	Body	Driver Door Switch																																								
K	2010	Sierra	Body	HVAC Control Module Auto																																								
K	2010	Sierra	Body	HVAC Control Module Manual																																								
K	2010	Sierra	Body	Instrument Panel Cluster																																								
K	2010	Sierra	Body	Memory Seat Module																																								
K	2010	Sierra	Body	Park Assist Module																																								
K	2010	Sierra	Body	Passenger Door Switch																																								
K	2010	Sierra	Body	Passenger Presence System																																								
K	2010	Sierra	Body	Radio																																								
K	2010	Sierra	Body	Rear Heated Seat Module																																								
K	2010	Sierra	Body	Rear HVAC/RSA																																								
K	2010	Sierra	Body	Supplemental Inflatable Restraint																																								
K	2010	Sierra	Body	Theft Deterrent Module																																								
K	2010	Sierra Hybrid	Powertrain	Engine Control Module																																								
K	2010	Sierra Hybrid	Powertrain	Accessory Power Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2010	Sierra Hybrid	Powertrain	Battery Energy Control Module																																								
K	2010	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																								
K	2010	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 1																																								
K	2010	Sierra Hybrid	Powertrain	Motor Control Modules 2																																								
K	2010	Sierra Hybrid	Powertrain	Transmission Control Module																																								
K	2010	Sierra Hybrid	Powertrain	Transfer Case Control Module																																								
K	2010	Sierra Hybrid	Chassis	Electronic Brake Control Module																																								
K	2010	Sierra Hybrid	Chassis	Electronic Suspension Control																																								
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Sierra Hybrid	Chassis	Power Steering Control Module																																								
K	2010	Sierra Hybrid	Body	A/C Compressor Control Module																																								
K	2010	Sierra Hybrid	Body	Amplifier (Bose)																																								
K	2010	Sierra Hybrid	Body	Body Control Module																																								
K	2010	Sierra Hybrid	Body	Body Control Module (aux.)																																								
K	2010	Sierra Hybrid	Body	Digital Radio Receiver																																								
K	2010	Sierra Hybrid	Body	Driver Door Switch																																								
K	2010	Sierra Hybrid	Body	Heated Seat Module																																								
K	2010	Sierra Hybrid	Body	HVAC Control Module																																								
K	2010	Sierra Hybrid	Body	Instrument Panel Cluster																																								
K	2010	Sierra Hybrid	Body	Park Assist Module																																								
K	2010	Sierra Hybrid	Body	Passenger Door Switch																																								
K	2010	Sierra Hybrid	Body	Passenger Presence System																																								
K	2010	Sierra Hybrid	Body	Radio																																								
K	2010	Sierra Hybrid	Body	Rear Heated Seat Module																																								
K	2010	Sierra Hybrid	Body	Rear HVAC/RSA																																								
K	2010	Sierra Hybrid	Body	Serial Data Gateway Module																																								
K	2010	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2010	Sierra Hybrid	Body	Theft Deterrent Module																																								
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
K	2010	Yukon	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																								
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2010	Yukon	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2010	Yukon	Chassis	Electronic Brake Control Module																																								
K	2010	Yukon	Chassis	Electronic Suspension Control																																								
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Yukon	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Yukon	Body	Amplifier (Bose)																																								
K	2010	Yukon	Body	Assist Step Controller																																								
K	2010	Yukon	Body	Body Control Module																																								
K	2010	Yukon	Body	Body Control Module (aux.)																																								
K	2010	Yukon	Body	Digital Radio Receiver																																								
K	2010	Yukon	Body	Driver Door Switch																																								
K	2010	Yukon	Body	HVAC Control Module Auto																																								
K	2010	Yukon	Body	HVAC Control Module Manual																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2010	Yukon	Body	Instrument Panel Cluster																																								
K	2010	Yukon	Body	Left Side Object Detection Module																																								
K	2010	Yukon	Body	Lift Gate Module																																								
K	2010	Yukon	Body	Memory Seat Module																																								
K	2010	Yukon	Body	Park Assist Module																																								
K	2010	Yukon	Body	Passenger Door Switch																																								
K	2010	Yukon	Body	Passenger Presence System																																								
K	2010	Yukon	Body	Radio																																								
K	2010	Yukon	Body	Rear Heated Seat Module																																								
K	2010	Yukon	Body	Rear HVAC/RSA																																								
K	2010	Yukon	Body	Right Side Object Detection Module																																								
K	2010	Yukon	Body	Supplemental Inflatable Restraint																																								
K	2010	Yukon	Body	Theft Deterrent Module																																								
K	2010	Yukon Hybrid	Powertrain	Engine Control Module																																								
K	2010	Yukon Hybrid	Powertrain	Accessory Power Module																																								
K	2010	Yukon Hybrid	Powertrain	Battery Energy Control Module																																								
K	2010	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																								
K	2010	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 1																																								
K	2010	Yukon Hybrid	Powertrain	Motor Control Modules 2																																								
K	2010	Yukon Hybrid	Powertrain	Transmission Control Module																																								
K	2010	Yukon Hybrid	Powertrain	Transfer Case Control Module																																								
K	2010	Yukon Hybrid	Chassis	Electronic Brake Control Module																																								
K	2010	Yukon Hybrid	Chassis	Electronic Suspension Control																																								
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Yukon Hybrid	Chassis	Power Steering Control Module																																								
K	2010	Yukon Hybrid	Body	A/C Compressor Control Module																																								
K	2010	Yukon Hybrid	Body	Amplifier (Bose)																																								
K	2010	Yukon Hybrid	Body	Body Control Module																																								
K	2010	Yukon Hybrid	Body	Body Control Module (aux.)																																								
K	2010	Yukon Hybrid	Body	Digital Radio Receiver																																								
K	2010	Yukon Hybrid	Body	Driver Door Switch																																								
K	2010	Yukon Hybrid	Body	Heated Seat Module																																								
K	2010	Yukon Hybrid	Body	HVAC Control Module																																								
K	2010	Yukon Hybrid	Body	Instrument Panel Cluster																																								
K	2010	Yukon Hybrid	Body	Left Side Object Detection Module																																								
K	2010	Yukon Hybrid	Body	Lift Gate Module																																								
K	2010	Yukon Hybrid	Body	Park Assist Module																																								
K	2010	Yukon Hybrid	Body	Passenger Door Switch																																								
K	2010	Yukon Hybrid	Body	Passenger Presence System																																								
K	2010	Yukon Hybrid	Body	Radio																																								
K	2010	Yukon Hybrid	Body	Rear Heated Seat Module																																								
K	2010	Yukon Hybrid	Body	Rear HVAC/RSA																																								
K	2010	Yukon Hybrid	Body	Right Side Object Detection Module																																								
K	2010	Yukon Hybrid	Body	Serial Data Gateway Module																																								
K	2010	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																								
K	2010	Yukon Hybrid	Body	Theft Deterrent Module																																								
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
K	2010	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
K	2010	Yukon XL	Powertrain	(F)6.2L V8 L94 Transfer Case Control Module																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 1 Speed																																								
K	2010	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module 2 Speed																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 1 Speed																																								
K	2010	Yukon XL	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module 2 Speed																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 1 Speed																																								
K	2010	Yukon XL	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module 2 Speed																																								
K	2010	Yukon XL	Chassis	EBCM under 8600 GVW																																								
K	2010	Yukon XL	Chassis	EBCM equal to or Over 8600 GVW																																								
K	2010	Yukon XL	Chassis	Electronic Suspension Control																																								
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Yukon XL	Chassis	FPCM with Trailer Brake Control																																								
K	2010	Yukon XL	Chassis	Trailer Brake Control Module																																								
K	2010	Yukon XL	Body	Amplifier (Bose)																																								
K	2010	Yukon XL	Body	Assist Step Controller																																								
K	2010	Yukon XL	Body	Body Control Module																																								
K	2010	Yukon XL	Body	Body Control Module (aux.)																																								
K	2010	Yukon XL	Body	Digital Radio Receiver																																								
K	2010	Yukon XL	Body	Driver Door Switch																																								
K	2010	Yukon XL	Body	HVAC Control Module Auto																																								
K	2010	Yukon XL	Body	HVAC Control Module Manual																																								
K	2010	Yukon XL	Body	Instrument Panel Cluster																																								
K	2010	Yukon XL	Body	Left Side Object Detection Module																																								
K	2010	Yukon XL	Body	Lift Gate Module																																								
K	2010	Yukon XL	Body	Memory Seat Module																																								
K	2010	Yukon XL	Body	Park Assist Module																																								
K	2010	Yukon XL	Body	Passenger Door Switch																																								
K	2010	Yukon XL	Body	Passenger Presence System																																								
K	2010	Yukon XL	Body	Radio																																								
K	2010	Yukon XL	Body	Rear Heated Seat Module																																								
K	2010	Yukon XL	Body	Rear HVAC/RSA																																								
K	2010	Yukon XL	Body	Right Side Object Detection Module																																								
K	2010	Yukon XL	Body	Supplemental Inflatable Restraint																																								
K	2010	Yukon XL	Body	Theft Deterrent Module																																								
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
L	2004	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																								
L	2004	ALL	Chassis	4WAL 3 Sensor																																								
L	2004	ALL	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2004	ALL	Body	Instrument Panel Cluster																																								
L	2004	ALL	Body	Supplemental Inflatable Restraint																																								
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
L	2005	ALL	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																								
L	2005	ALL	Chassis	4WAL 3 Sensor																																								
L	2005	ALL	Body	Body Control Module																																								
L	2005	ALL	Body	Instrument Panel Cluster																																								
L	2005	ALL	Body	Supplemental Inflatable Restraint																																								
L	2010	Terrain	Powertrain	(W) 2.4L LAF Engine Control Module																																								
L	2010	Terrain	Powertrain	(W) 2.4L LAF Transmission Control Module																																								
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Engine Control Module																																								
L	2010	Terrain	Powertrain	(Y) 3.0L LF1 Transmission Control Module																																								
L	2010	Terrain	Powertrain	Fuel Pump Control Module																																								
L	2010	Terrain	Powertrain	Rear Differential Clutch Control Module																																								
L	2010	Terrain	Chassis	Electronic Brake Control Module																																								
L	2010	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2010	Terrain	Chassis	Steering Wheel Angle Sensor Module																																								
L	2010	Terrain	Body	Body Control Module																																								
L	2010	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2010	Terrain	Body	Passenger Presence Module																																								
L	2010	Terrain	Body	Instrument Cluster																																								
L	2010	Terrain	Body	Radio																																								
L	2010	Terrain	Body	Multimedia Player Interface Module																																								
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 8																																								
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 9																																								
L	2010	Terrain	Body	Telematics Communication Interface Control Module Version 10																																								
L	2010	Terrain	Body	HVAC Control Module Auto Single (C68)																																								
L	2010	Terrain	Body	HVAC Control Module Manual Single (C67)																																								
L	2010	Terrain	Body	Liftgate Control Module																																								
L	2010	Terrain	Body	Parking Assist Control Module																																								
L	2010	Terrain	Body	Frontview Camera Module																																								
L	2010	Terrain	Body	Vehicle Direction Camera Control Module																																								
L	2011	Terrain	Powertrain	(C) 2.4L LAF Engine Control Module																																								
L	2011	Terrain	Powertrain	(C) 2.4L LAF Transmission Control Module																																								
L	2011	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																								
L	2011	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
L	2011	Terrain	Powertrain	Fuel Pump Control Module																																								
L	2011	Terrain	Powertrain	Rear Differential Clutch Control Module																																								
L	2011	Terrain	Chassis	Electronic Brake Control Module																																								
L	2011	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2011	Terrain	Chassis	Steering Wheel Angle Sensor Module																																								
L	2011	Terrain	Body	Body Control Module																																								
L	2011	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2011	Terrain	Body	Passenger Presence Module																																								
L	2011	Terrain	Body	Instrument Cluster																																								
L	2011	Terrain	Body	Radio																																								
L	2011	Terrain	Body	Multimedia Player Interface Module																																								
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 9																																								
L	2011	Terrain	Body	Telematics Communication Interface Control Module Version 10																																								
L	2011	Terrain	Body	HVAC Control Module Auto Single (C68)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2011	Terrain	Body	HVAC Control Module Manual Single (C67)																																								
L	2011	Terrain	Body	Liftgate Control Module																																								
L	2011	Terrain	Body	Parking Assist Control Module																																								
L	2011	Terrain	Body	Frontview Camera Module																																								
L	2011	Terrain	Body	Vehicle Direction Camera Control Module																																								
L	2012	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																								
L	2012	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
L	2012	Terrain	Powertrain	(5) 3.0L LFW Engine Control Module																																								
L	2012	Terrain	Powertrain	(5) 3.0L LFW Transmission Control Module																																								
L	2012	Terrain	Powertrain	Fuel Pump Control Module																																								
L	2012	Terrain	Powertrain	Rear Differential Clutch Control Module																																								
L	2012	Terrain	Chassis	Electronic Brake Control Module																																								
L	2012	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2012	Terrain	Chassis	Steering Wheel Angle Sensor Module																																								
L	2012	Terrain	Body	Body Control Module																																								
L	2012	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2012	Terrain	Body	Passenger Presence Module																																								
L	2012	Terrain	Body	Instrument Cluster																																								
L	2012	Terrain	Body	Radio																																								
L	2012	Terrain	Body	Multimedia Player Interface Module																																								
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 9																																								
L	2012	Terrain	Body	Telematics Communication Interface Control Module Version 10																																								
L	2012	Terrain	Body	HVAC Control Module Auto Single (C68)																																								
L	2012	Terrain	Body	HVAC Control Module Manual Single (C67)																																								
L	2012	Terrain	Body	Liftgate Control Module																																								
L	2012	Terrain	Body	Parking Assist Control Module																																								
L	2012	Terrain	Body	Frontview Camera Module																																								
L	2012	Terrain	Body	Vehicle Direction Camera Control Module																																								
L	2013	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																								
L	2013	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
L	2013	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																								
L	2013	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
L	2013	Terrain	Powertrain	Rear Differential Clutch Control Module																																								
L	2013	Terrain	Chassis	Electronic Brake Control Module																																								
L	2013	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2013	Terrain	Chassis	Power Steering Control Module																																								
L	2013	Terrain	Chassis	Steering Wheel Angle Sensor Module																																								
L	2013	Terrain	Body	Body Control Module Mechanical Liftgate																																								
L	2013	Terrain	Body	Body Control Module Power Liftgate (TB5)																																								
L	2013	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2013	Terrain	Body	Passenger Presence Module																																								
L	2013	Terrain	Body	Instrument Cluster																																								
L	2013	Terrain	Body	Radio																																								
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 9																																								
L	2013	Terrain	Body	Telematics Communication Interface Control Module Version 10																																								
L	2013	Terrain	Body	HVAC Control Module Auto Single (C68)																																								
L	2013	Terrain	Body	HVAC Control Module Manual Single (C67)																																								
L	2013	Terrain	Body	Liftgate Control Module																																								
L	2013	Terrain	Body	Right Side Object Detection Control Module																																								
L	2013	Terrain	Body	Left Side Object Detection Control Module																																								
L	2013	Terrain	Body	Parking Assist Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2013	Terrain	Body	Frontview Camera Module																																								
L	2014	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																								
L	2014	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
L	2014	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																								
L	2014	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
L	2014	Terrain	Powertrain	Rear Differential Clutch Control Module																																								
L	2014	Terrain	Chassis	Electronic Brake Control Module																																								
L	2014	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2014	Terrain	Chassis	Power Steering Control Module																																								
L	2014	Terrain	Chassis	Steering Wheel Angle Sensor Module																																								
L	2014	Terrain	Body	Body Control Module Mechanical Liftgate																																								
L	2014	Terrain	Body	Body Control Module Power Liftgate (TB5)																																								
L	2014	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2014	Terrain	Body	Passenger Presence Module																																								
L	2014	Terrain	Body	Instrument Cluster																																								
L	2014	Terrain	Body	Radio																																								
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 9																																								
L	2014	Terrain	Body	Telematics Communication Interface Control Module Version 10																																								
L	2014	Terrain	Body	HVAC Control Module Auto Single (C68)																																								
L	2014	Terrain	Body	HVAC Control Module Manual Single (C67)																																								
L	2014	Terrain	Body	Liftgate Control Module																																								
L	2014	Terrain	Body	Right Side Object Detection Control Module																																								
L	2014	Terrain	Body	Left Side Object Detection Control Module																																								
L	2014	Terrain	Body	Parking Assist Control Module																																								
L	2014	Terrain	Body	Frontview Camera Module																																								
L	2015	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																								
L	2015	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																								
L	2015	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																								
L	2015	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
L	2015	Terrain	Powertrain	Rear Differential Clutch Control Module																																								
L	2015	Terrain	Chassis	Electronic Brake Control Module																																								
L	2015	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2015	Terrain	Chassis	Power Steering Control Module																																								
L	2015	Terrain	Chassis	Steering Wheel Angle Sensor Module																																								
L	2015	Terrain	Body	Body Control Module Mechanical Liftgate																																								
L	2015	Terrain	Body	Body Control Module Power Liftgate (TB5)																																								
L	2015	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2015	Terrain	Body	Passenger Presence Module																																								
L	2015	Terrain	Body	Instrument Cluster																																								
L	2015	Terrain	Body	Radio																																								
L	2015	Terrain	Body	Telematics Communication Interface Control Module																																								
L	2015	Terrain	Body	HVAC Control Module Auto Single (C68)																																								
L	2015	Terrain	Body	HVAC Control Module Manual Single (C67)																																								
L	2015	Terrain	Body	Liftgate Control Module																																								
L	2015	Terrain	Body	Seat Memory Control Module																																								
L	2015	Terrain	Body	Right Side Object Detection Control Module																																								
L	2015	Terrain	Body	Left Side Object Detection Control Module																																								
L	2015	Terrain	Body	Parking Assist Control Module																																								
L	2015	Terrain	Body	Frontview Camera Module																																								
L	2016	Terrain	Powertrain	(K) 2.4L LEA Engine Control Module																																								
L	2016	Terrain	Powertrain	(K) 2.4L LEA Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
L	2016	Terrain	Powertrain	(3) 3.6L LFX Engine Control Module																																								
L	2016	Terrain	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
L	2016	Terrain	Powertrain	Rear Differential Clutch Control Module																																								
L	2016	Terrain	Chassis	Electronic Brake Control Module																																								
L	2016	Terrain	Chassis	Multi-Axis Acceleration Sensor Module																																								
L	2016	Terrain	Chassis	Power Steering Control Module																																								
L	2016	Terrain	Chassis	Steering Wheel Angle Sensor Module																																								
L	2016	Terrain	Body	Body Control Module Mechanical Liftgate																																								
L	2016	Terrain	Body	Body Control Module Power Liftgate (TB5)																																								
L	2016	Terrain	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
L	2016	Terrain	Body	Passenger Presence Module																																								
L	2016	Terrain	Body	Instrument Cluster																																								
L	2016	Terrain	Body	Radio																																								
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 9.7																																								
L	2016	Terrain	Body	Telematics Communication Interface Control Module Version 10																																								
L	2016	Terrain	Body	HVAC Control Module Auto Single (C68)																																								
L	2016	Terrain	Body	HVAC Control Module Manual Single (C67)																																								
L	2016	Terrain	Body	Liftgate Control Module																																								
L	2016	Terrain	Body	Seat Memory Control Module																																								
L	2016	Terrain	Body	Right Side Object Detection Control Module																																								
L	2016	Terrain	Body	Left Side Object Detection Control Module																																								
L	2016	Terrain	Body	Parking Assist Control Module																																								
L	2016	Terrain	Body	Frontview Camera Module																																								
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
M	2004	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
M	2004	ALL	Chassis	4WAL 3 Sensor																																								
M	2004	ALL	Body	Body Control Module																																								
M	2004	ALL	Body	Instrument Panel Cluster																																								
M	2004	ALL	Body	Supplemental Inflatable Restraint																																								
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
M	2005	ALL	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
M	2005	ALL	Chassis	4WAL 3 Sensor																																								
M	2005	ALL	Body	Body Control Module																																								
M	2005	ALL	Body	Instrument Panel Cluster																																								
M	2005	ALL	Body	Supplemental Inflatable Restraint																																								
P	2005	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																								
P	2006	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																								
P	2007	ALL	Powertrain	(R)5.7L V8 L31 Engine Control Module																																								
P	2007	ALL	Body	Supplemental Inflatable Restraint																																								
P	2007	ALL	Body	Theft Deterrent Module																																								
R	2007	ALL	Powertrain	Engine Control Module																																								
R	2007	ALL	Powertrain	Transmission Control Module																																								
R	2007	ALL	Chassis	Electronic Brake Control Module																																								
R	2007	ALL	Body	Body Control Module																																								
R	2007	ALL	Body	Digital Radio Receiver																																								
R	2007	ALL	Body	Driver Door Switch																																								
R	2007	ALL	Body	Head Up Display																																								
R	2007	ALL	Body	Heated Seat Module																																								
R	2007	ALL	Body	HVAC Control Module Auto																																								
R	2007	ALL	Body	HVAC Control Module Manual																																								
R	2007	ALL	Body	Instrument Panel Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Thefflock LED
R	2007	ALL	Body	Lift Gate Module																																								
R	2007	ALL	Body	Park Assist Module																																								
R	2007	ALL	Body	Passenger Door Switch																																								
R	2007	ALL	Body	Passenger Presence System																																								
R	2007	ALL	Body	Radio																																								
R	2007	ALL	Body	Rear HVAC/RSA																																								
R	2007	ALL	Body	Rollover Sensor																																								
R	2007	ALL	Body	Supplemental Inflatable Restraint																																								
R	2007	ALL	Body	Theft Deterrent Module																																								
R	2008	ALL	Powertrain	Engine Control Module																																								
R	2008	ALL	Powertrain	Transmission Control Module																																								
R	2008	ALL	Chassis	Electronic Brake Control Module																																								
R	2008	ALL	Body	Body Control Module																																								
R	2008	ALL	Body	Digital Radio Receiver																																								
R	2008	ALL	Body	Driver Door Switch																																								
R	2008	ALL	Body	Head Up Display																																								
R	2008	ALL	Body	Heated Seat Module																																								
R	2008	ALL	Body	HVAC Control Module Auto																																								
R	2008	ALL	Body	HVAC Control Module Manual																																								
R	2008	ALL	Body	Instrument Panel Cluster																																								
R	2008	ALL	Body	Lift Gate Module																																								
R	2008	ALL	Body	Park Assist Module																																								
R	2008	ALL	Body	Passenger Door Switch																																								
R	2008	ALL	Body	Passenger Presence System																																								
R	2008	ALL	Body	Radio																																								
R	2008	ALL	Body	Rear HVAC/RSA																																								
R	2008	ALL	Body	Rollover Sensor																																								
R	2008	ALL	Body	Supplemental Inflatable Restraint																																								
R	2008	ALL	Body	Theft Deterrent Module																																								
R	2009	ALL	Powertrain	Engine Control Module																																								
R	2009	ALL	Powertrain	Fuel Pump Control Module																																								
R	2009	ALL	Powertrain	Transmission Control Module																																								
R	2009	ALL	Chassis	Electronic Brake Control Module																																								
R	2009	ALL	Body	Body Control Module																																								
R	2009	ALL	Body	Digital Radio Receiver																																								
R	2009	ALL	Body	Driver Door Switch				V																																				
R	2009	ALL	Body	Head Up Display																																								
R	2009	ALL	Body	Heated Seat Module																																								
R	2009	ALL	Body	HVAC Control Module Auto																																								
R	2009	ALL	Body	HVAC Control Module Manual																																								
R	2009	ALL	Body	Instrument Panel Cluster																																								
R	2009	ALL	Body	Lift Gate Module																																								
R	2009	ALL	Body	Park Assist Module																																								
R	2009	ALL	Body	Passenger Door Switch				V																																				
R	2009	ALL	Body	Passenger Presence System																																								
R	2009	ALL	Body	Radio																																								
R	2009	ALL	Body	Rear HVAC/RSA																																								
R	2009	ALL	Body	Rollover Sensor																																								
R	2009	ALL	Body	Supplemental Inflatable Restraint																																								
R	2009	ALL	Body	Theft Deterrent Module																																								
R	2010	ALL	Powertrain	Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
R	2010	ALL	Powertrain	Fuel Pump Control Module																																								
R	2010	ALL	Powertrain	Transmission Control Module																																								
R	2010	ALL	Chassis	Electronic Brake Control Module																																								
R	2010	ALL	Body	Body Control Module																																								
R	2010	ALL	Body	Digital Radio Receiver																																								
R	2010	ALL	Body	Driver Door Switch				V																																				
R	2010	ALL	Body	Head Up Display																																								
R	2010	ALL	Body	Heated Seat Module																																								
R	2010	ALL	Body	HVAC Control Module Auto																																								
R	2010	ALL	Body	HVAC Control Module Manual																																								
R	2010	ALL	Body	Instrument Panel Cluster																																								
R	2010	ALL	Body	Lift Gate Module																																								
R	2010	ALL	Body	Park Assist Module																																								
R	2010	ALL	Body	Passenger Door Switch				V																																				
R	2010	ALL	Body	Passenger Presence System																																								
R	2010	ALL	Body	Radio																																								
R	2010	ALL	Body	Rear HVAC/RSA																																								
R	2010	ALL	Body	Supplemental Inflatable Restraint																																								
R	2010	ALL	Body	Theft Deterrent Module																																								
R	2011	ALL	Powertrain	Engine Control Module																																								
R	2011	ALL	Powertrain	Fuel Pump Control Module																																								
R	2011	ALL	Powertrain	Transmission Control Module																																								
R	2011	ALL	Chassis	Electronic Brake Control Module																																								
R	2011	ALL	Body	Body Control Module																																								
R	2011	ALL	Body	Digital Radio Receiver																																								
R	2011	ALL	Body	Driver Door Switch				V																																				
R	2011	ALL	Body	Head Up Display																																								
R	2011	ALL	Body	Heated Seat Module																																								
R	2011	ALL	Body	HVAC Control Module Auto																																								
R	2011	ALL	Body	HVAC Control Module Manual																																								
R	2011	ALL	Body	Instrument Panel Cluster																																								
R	2011	ALL	Body	Lift Gate Module																																								
R	2011	ALL	Body	Park Assist Module																																								
R	2011	ALL	Body	Passenger Door Switch				V																																				
R	2011	ALL	Body	Passenger Presence System																																								
R	2011	ALL	Body	Radio																																								
R	2011	ALL	Body	Rear HVAC/RSA																																								
R	2011	ALL	Body	Supplemental Inflatable Restraint																																								
R	2011	ALL	Body	Theft Deterrent Module																																								
R	2012	ALL	Powertrain	Engine Control Module																																								
R	2012	ALL	Powertrain	Fuel Pump Control Module																																								
R	2012	ALL	Powertrain	Transmission Control Module																																								
R	2012	ALL	Chassis	Electronic Brake Control Module																																								
R	2012	ALL	Body	Body Control Module																																								
R	2012	ALL	Body	Digital Radio Receiver																																								
R	2012	ALL	Body	Driver Door Switch				V																																				
R	2012	ALL	Body	Head Up Display																																								
R	2012	ALL	Body	Heated Seat Module																																								
R	2012	ALL	Body	HVAC Control Module Auto																																								
R	2012	ALL	Body	HVAC Control Module Manual																																								
R	2012	ALL	Body	Instrument Panel Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
R	2012	ALL	Body	Lift Gate Module																																								
R	2012	ALL	Body	Park Assist Module																																								
R	2012	ALL	Body	Passenger Door Switch				V																																				
R	2012	ALL	Body	Passenger Presence System																																								
R	2012	ALL	Body	Radio																																								
R	2012	ALL	Body	Rear HVAC/RSA																																								
R	2012	ALL	Body	Supplemental Inflatable Restraint																																								
R	2012	ALL	Body	Theft Deterrent Module																																								
R	2013	ALL	Powertrain	Engine Control Module																																								
R	2013	ALL	Powertrain	Fuel Pump Control Module																																								
R	2013	ALL	Powertrain	Transmission Control Module																																								
R	2013	ALL	Chassis	Electronic Brake Control Module																																								
R	2013	ALL	Body	Body Control Module																																								
R	2013	ALL	Body	Digital Radio Receiver																																								
R	2013	ALL	Body	Driver Door Switch				V																																				
R	2013	ALL	Body	Head Up Display																																								
R	2013	ALL	Body	Heated Seat Module																																								
R	2013	ALL	Body	HVAC Control Module Auto																																								
R	2013	ALL	Body	HVAC Control Module Manual																																								
R	2013	ALL	Body	Instrument Panel Cluster																																								
R	2013	ALL	Body	Left Side Object Detection Module																																								
R	2013	ALL	Body	Lift Gate Module																																								
R	2013	ALL	Body	Park Assist Module																																								
R	2013	ALL	Body	Passenger Door Switch				V																																				
R	2013	ALL	Body	Passenger Presence System																																								
R	2013	ALL	Body	Radio																																								
R	2013	ALL	Body	Rear HVAC/RSA																																								
R	2013	ALL	Body	Right Side Object Detection Module																																								
R	2013	ALL	Body	Supplemental Inflatable Restraint																																								
R	2013	ALL	Body	Theft Deterrent Module																																								
R	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																								
R	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
R	2014	Acadia	Powertrain	Chassis Control Module																																								
R	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																								
R	2014	Acadia	Chassis	Electronic Brake Control Module																																								
R	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																								
R	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																								
R	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
R	2014	Acadia	Body	Passenger Presence Module																																								
R	2014	Acadia	Body	Instrument Cluster																																								
R	2014	Acadia	Body	Head-Up Display Module																																								
R	2014	Acadia	Body	Radio																																								
R	2014	Acadia	Body	Rear Audio Control Module																																								
R	2014	Acadia	Body	Digital Radio Receiver Control Module																																								
R	2014	Acadia	Body	Personal Audio Link Control Module																																								
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																								
R	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																								
R	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																								
R	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																								
R	2014	Acadia	Body	Driver Door Switch Panel Control Module																																								
R	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
R	2014	Acadia	Body	Liftgate Control Module																																								
R	2014	Acadia	Body	Seat Memory Control Module																																								
R	2014	Acadia	Body	Front Seat Heating Control Module																																								
R	2014	Acadia	Body	Right Side Object Detection Control Module																																								
R	2014	Acadia	Body	Left Side Object Detection Control Module																																								
R	2014	Acadia	Body	Remote Control Door Lock Receiver																																								
R	2014	Acadia	Body	Parking Assist Control Module																																								
R	2014	Acadia	Body	Frontview Camera Module																																								
R	2014	Acadia	Body	Theft Deterrent Module																																								
R	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																								
R	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
R	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																								
R	2015	Acadia	Chassis	Electronic Brake Control Module																																								
R	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																								
R	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																								
R	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
R	2015	Acadia	Body	Passenger Presence Module																																								
R	2015	Acadia	Body	Instrument Cluster																																								
R	2015	Acadia	Body	Head-Up Display Module																																								
R	2015	Acadia	Body	Radio																																								
R	2015	Acadia	Body	Rear Audio Control Module																																								
R	2015	Acadia	Body	Digital Radio Receiver Control Module																																								
R	2015	Acadia	Body	Personal Audio Link Control Module																																								
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																								
R	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																								
R	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																								
R	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																								
R	2015	Acadia	Body	Driver Door Switch Panel Control Module																																								
R	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																								
R	2015	Acadia	Body	Liftgate Control Module																																								
R	2015	Acadia	Body	Seat Memory Control Module																																								
R	2015	Acadia	Body	Front Seat Heating Control Module																																								
R	2015	Acadia	Body	Right Side Object Detection Control Module																																								
R	2015	Acadia	Body	Left Side Object Detection Control Module																																								
R	2015	Acadia	Body	Remote Control Door Lock Receiver																																								
R	2015	Acadia	Body	Parking Assist Control Module																																								
R	2015	Acadia	Body	Frontview Camera Module																																								
R	2015	Acadia	Body	Theft Deterrent Module																																								
R	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																								
R	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
R	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																								
R	2016	Acadia	Chassis	Electronic Brake Control Module																																								
R	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																								
R	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																								
R	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
R	2016	Acadia	Body	Passenger Presence Module																																								
R	2016	Acadia	Body	Instrument Cluster																																								
R	2016	Acadia	Body	Head-Up Display Module																																								
R	2016	Acadia	Body	Radio																																								
R	2016	Acadia	Body	Rear Audio Control Module																																								
R	2016	Acadia	Body	Digital Radio Receiver Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
R	2016	Acadia	Body	Personal Audio Link Control Module																																								
R	2016	Acadia	Body	Telematics Communication Interface Control Module																																								
R	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																								
R	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																								
R	2016	Acadia	Body	Driver Door Switch Panel Control Module																																								
R	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																								
R	2016	Acadia	Body	Liftgate Control Module																																								
R	2016	Acadia	Body	Seat Memory Control Module																																								
R	2016	Acadia	Body	Front Seat Heating Control Module																																								
R	2016	Acadia	Body	Right Side Object Detection Control Module																																								
R	2016	Acadia	Body	Left Side Object Detection Control Module																																								
R	2016	Acadia	Body	Remote Control Door Lock Receiver																																								
R	2016	Acadia	Body	Parking Assist Control Module																																								
R	2016	Acadia	Body	Frontview Camera Module																																								
R	2016	Acadia	Body	Theft Deterrent Module																																								
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
S	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
S	2004	Sonoma	Chassis	4WAL 3 Sensor																																								
S	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																								
S	2004	Sonoma	Body	Body Control Module																																								
S	2004	Sonoma	Body	Instrument Panel Cluster																																								
S	2004	Sonoma	Body	Base Radio																																								
S	2004	Sonoma	Body	Uplevel Radio																																								
S	2004	Sonoma	Body	Supplemental Inflatable Restraint																																								
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																								
S	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																								
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																								
S	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																								
S	2004	Canyon	Chassis	ABS Without Traction Control																																								
S	2004	Canyon	Chassis	ABS With Traction Control																																								
S	2004	Canyon	Body	Body Control Module																																								
S	2004	Canyon	Body	Instrument Panel Cluster																																								
S	2004	Canyon	Body	OnStar																																								
S	2004	Canyon	Body	Base Radio																																								
S	2004	Canyon	Body	Uplevel Radio																																								
S	2004	Canyon	Body	Supplemental Inflatable Restraint																																								
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2004	Envoy	Chassis	ABS Without Traction Control																																								
S	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
S	2004	Envoy	Chassis	Traction Assist (If Equipped)																																								
S	2004	Envoy	Body	Amplifier (Bose)																																								
S	2004	Envoy	Body	Body Control Module																																								
S	2004	Envoy	Body	Driver Door Module																																								
S	2004	Envoy	Body	Driver Seat Module																																								
S	2004	Envoy	Body	Heating and Air Conditioning Auto					V																																			
S	2004	Envoy	Body	Heating and Air Conditioning Manual																																								
S	2004	Envoy	Body	Instrument Panel Cluster																																								
S	2004	Envoy	Body	Lift Gate Module																																								
S	2004	Envoy	Body	OnStar																																								
S	2004	Envoy	Body	Passenger Door Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2004	Envoy	Body	Uplevel Radio																																								
S	2004	Envoy	Body	Navigation Radio																																								
S	2004	Envoy	Body	Rear Seat Audio																																								
S	2004	Envoy	Body	Rear Seat Entertainment																																								
S	2004	Envoy	Body	Supplemental Inflatable Restraint																																								
S	2004	Envoy	Body	Vehicle Theft Deterrent																																								
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																								
S	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																								
S	2004	Envoy XL	Chassis	ABS Without Traction Control																																								
S	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
S	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																								
S	2004	Envoy XL	Body	Amplifier (Bose)																																								
S	2004	Envoy XL	Body	Body Control Module																																								
S	2004	Envoy XL	Body	Driver Door Module																																								
S	2004	Envoy XL	Body	Driver Seat Module																																								
S	2004	Envoy XL	Body	Heating and Air Conditioning Auto					V																																			
S	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																								
S	2004	Envoy XL	Body	Instrument Panel Cluster																																								
S	2004	Envoy XL	Body	Lift Gate Module																																								
S	2004	Envoy XL	Body	OnStar																																								
S	2004	Envoy XL	Body	Passenger Door Module																																								
S	2004	Envoy XL	Body	Uplevel Radio																																								
S	2004	Envoy XL	Body	Navigation Radio																																								
S	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																								
S	2004	Envoy XL	Body	Rear HVAC Manual																																								
S	2004	Envoy XL	Body	Rear Seat Entertainment																																								
S	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																								
S	2004	Envoy XL	Body	Vehicle Theft Deterrent																																								
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																								
S	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																								
S	2004	Envoy XUV	Chassis	ABS Without Traction Control																																								
S	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
S	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																								
S	2004	Envoy XUV	Body	Amplifier (Bose)																																								
S	2004	Envoy XUV	Body	Body Control Module																																								
S	2004	Envoy XUV	Body	Driver Door Module																																								
S	2004	Envoy XUV	Body	Driver Seat Module																																								
S	2004	Envoy XUV	Body	Heating and Air Conditioning Auto					V																																			
S	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																								
S	2004	Envoy XUV	Body	Instrument Panel Cluster																																								
S	2004	Envoy XUV	Body	Lift Gate Module																																								
S	2004	Envoy XUV	Body	OnStar																																								
S	2004	Envoy XUV	Body	Passenger Door Module																																								
S	2004	Envoy XUV	Body	Uplevel Radio																																								
S	2004	Envoy XUV	Body	Navigation Radio																																								
S	2004	Envoy XUV	Body	Rear Seat Audio																																								
S	2004	Envoy XUV	Body	Rear Seat Entertainment																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																								
S	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																								
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
S	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
S	2004	Jimmy	Chassis	4WAL 3 Sensor																																								
S	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																								
S	2004	Jimmy	Body	Body Control Module																																								
S	2004	Jimmy	Body	Heating and Air Conditioning																																								
S	2004	Jimmy	Body	Instrument Panel Cluster																																								
S	2004	Jimmy	Body	Memory Seat Module																																								
S	2004	Jimmy	Body	Base Radio																																								
S	2004	Jimmy	Body	Uplevel Radio																																								
S	2004	Jimmy	Body	Supplemental Inflatable Restraint																																								
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																								
S	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																								
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																								
S	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																								
S	2005	Canyon	Chassis	ABS Without Traction Control																																								
S	2005	Canyon	Chassis	ABS With Traction Control																																								
S	2005	Canyon	Body	Body Control Module																																								
S	2005	Canyon	Body	Instrument Panel Cluster																																								
S	2005	Canyon	Body	Base Radio																																								
S	2005	Canyon	Body	Uplevel Radio																																								
S	2005	Canyon	Body	Supplemental Inflatable Restraint																																								
S	2005	Canyon	Body	Vehicle Comm. Interface Module																																								
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
S	2005	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2005	Envoy	Chassis	ABS Without Traction Control																																								
S	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
S	2005	Envoy	Chassis	Traction Assist (If Equipped)																																								
S	2005	Envoy	Body	Body Control Module																																								
S	2005	Envoy	Body	Disc Player and Video Display																																								
S	2005	Envoy	Body	Driver Door Module																																								
S	2005	Envoy	Body	Driver Seat Module																																								
S	2005	Envoy	Body	Heating and Air Conditioning Auto					V																																			
S	2005	Envoy	Body	Heating and Air Conditioning Manual																																								
S	2005	Envoy	Body	Instrument Panel Cluster																																								
S	2005	Envoy	Body	Lift Gate Module																																								
S	2005	Envoy	Body	Passenger Door Module																																								
S	2005	Envoy	Body	Passenger Presence System																																								
S	2005	Envoy	Body	Uplevel Radio																																								
S	2005	Envoy	Body	Navigation Radio																																								
S	2005	Envoy	Body	Rear Seat Audio																																								
S	2005	Envoy	Body	Supplemental Inflatable Restraint																																								
S	2005	Envoy	Body	Vehicle Comm. Interface Module																																								
S	2005	Envoy	Body	Vehicle Theft Deterrent																																								
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2005	Envoy XL	Chassis	ABS Without Traction Control																																								
S	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
S	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																								
S	2005	Envoy XL	Body	Body Control Module																																								
S	2005	Envoy XL	Body	Disc Player and Video Display																																								
S	2005	Envoy XL	Body	Driver Door Module																																								
S	2005	Envoy XL	Body	Driver Seat Module																																								
S	2005	Envoy XL	Body	Heating and Air Conditioning Auto					V																																			
S	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																								
S	2005	Envoy XL	Body	Instrument Panel Cluster																																								
S	2005	Envoy XL	Body	Lift Gate Module																																								
S	2005	Envoy XL	Body	Passenger Door Module																																								
S	2005	Envoy XL	Body	Passenger Presence System																																								
S	2005	Envoy XL	Body	Uplevel Radio																																								
S	2005	Envoy XL	Body	Navigation Radio																																								
S	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																								
S	2005	Envoy XL	Body	Rear HVAC Manual																																								
S	2005	Envoy XL	Body	Rear Seat Audio																																								
S	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																								
S	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																								
S	2005	Envoy XL	Body	Vehicle Theft Deterrent																																								
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
S	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2005	Envoy XUV	Chassis	ABS Without Traction Control																																								
S	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
S	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																								
S	2005	Envoy XUV	Body	Body Control Module																																								
S	2005	Envoy XUV	Body	Disc Player and Video Display																																								
S	2005	Envoy XUV	Body	Driver Door Module																																								
S	2005	Envoy XUV	Body	Driver Seat Module																																								
S	2005	Envoy XUV	Body	Heating and Air Conditioning Auto					V																																			
S	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																								
S	2005	Envoy XUV	Body	Instrument Panel Cluster																																								
S	2005	Envoy XUV	Body	Lift Gate Module																																								
S	2005	Envoy XUV	Body	Passenger Door Module																																								
S	2005	Envoy XUV	Body	Passenger Presence System																																								
S	2005	Envoy XUV	Body	Uplevel Radio																																								
S	2005	Envoy XUV	Body	Navigation Radio																																								
S	2005	Envoy XUV	Body	Rear Seat Audio																																								
S	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																								
S	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																								
S	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																								
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
S	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
S	2005	Jimmy	Chassis	4WAL 3 Sensor																																								
S	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																								
S	2005	Jimmy	Body	Body Control Module																																								
S	2005	Jimmy	Body	Heating and Air Conditioning																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2005	Jimmy	Body	Instrument Panel Cluster																																								
S	2005	Jimmy	Body	Memory Seat Module																																								
S	2005	Jimmy	Body	Base Radio																																								
S	2005	Jimmy	Body	Uplevel Radio																																								
S	2005	Jimmy	Body	Supplemental Inflatable Restraint																																								
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
S	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
S	2005	Sonoma	Chassis	4WAL 3 Sensor																																								
S	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																								
S	2005	Sonoma	Body	Body Control Module																																								
S	2005	Sonoma	Body	Instrument Panel Cluster																																								
S	2005	Sonoma	Body	Base Radio																																								
S	2005	Sonoma	Body	Uplevel Radio																																								
S	2005	Sonoma	Body	Supplemental Inflatable Restraint																																								
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																								
S	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																								
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																								
S	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																								
S	2006	Canyon	Chassis	ABS Without Traction Control																																								
S	2006	Canyon	Chassis	ABS With Traction Control																																								
S	2006	Canyon	Body	Body Control Module																																								
S	2006	Canyon	Body	Instrument Panel Cluster																																								
S	2006	Canyon	Body	Passenger Presence System																																								
S	2006	Canyon	Body	Base Radio																																								
S	2006	Canyon	Body	Uplevel Radio																																								
S	2006	Canyon	Body	Supplemental Inflatable Restraint																																								
S	2006	Canyon	Body	Vehicle Comm. Interface Module																																								
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
S	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
S	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
S	2006	Envoy	Chassis	ABS/TCS/VSES																																								
S	2006	Envoy	Chassis	Tire Pressure Monitor																																								
S	2006	Envoy	Body	Body Control Module																																								
S	2006	Envoy	Body	Disc Player and Video Display																																								
S	2006	Envoy	Body	Driver Door Module																																								
S	2006	Envoy	Body	Driver Seat Module																																								
S	2006	Envoy	Body	Heating and Air Conditioning Auto					V																																			
S	2006	Envoy	Body	Heating and Air Conditioning Manual																																								
S	2006	Envoy	Body	Instrument Panel Cluster																																								
S	2006	Envoy	Body	Lift Gate Module																																								
S	2006	Envoy	Body	Passenger Door Module																																								
S	2006	Envoy	Body	Passenger Presence System																																								
S	2006	Envoy	Body	Uplevel Radio																																								
S	2006	Envoy	Body	Navigation Radio																																								
S	2006	Envoy	Body	Rear Seat Audio																																								
S	2006	Envoy	Body	Supplemental Inflatable Restraint																																								
S	2006	Envoy	Body	Vehicle Theft Deterrent																																								
S	2006	Envoy	Body	Vehicle Comm. Interface Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
S	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2006	Envoy XL	Chassis	ABS/TCS/VSES																																								
S	2006	Envoy XL	Body	Body Control Module																																								
S	2006	Envoy XL	Body	Disc Player and Video Display																																								
S	2006	Envoy XL	Body	Driver Door Module																																								
S	2006	Envoy XL	Body	Driver Seat Module																																								
S	2006	Envoy XL	Body	Heating and Air Conditioning Auto					V																																			
S	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																								
S	2006	Envoy XL	Body	Instrument Panel Cluster																																								
S	2006	Envoy XL	Body	Lift Gate Module																																								
S	2006	Envoy XL	Body	Passenger Door Module																																								
S	2006	Envoy XL	Body	Passenger Presence System																																								
S	2006	Envoy XL	Body	Uplevel Radio																																								
S	2006	Envoy XL	Body	Navigation Radio																																								
S	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																								
S	2006	Envoy XL	Body	Rear HVAC Manual																																								
S	2006	Envoy XL	Body	Rear Seat Audio																																								
S	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																								
S	2006	Envoy XL	Body	Vehicle Theft Deterrent																																								
S	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																								
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
S	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
S	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
S	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																								
S	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																								
S	2007	Canyon	Body	Body Control Module																																								
S	2007	Canyon	Body	Digital Radio Receiver																																								
S	2007	Canyon	Body	Generator Battery Control Module																																								
S	2007	Canyon	Body	Instrument Panel Cluster																																								
S	2007	Canyon	Body	Passenger Presence System																																								
S	2007	Canyon	Body	Base Radio																																								
S	2007	Canyon	Body	Uplevel Radio																																								
S	2007	Canyon	Body	Supplemental Inflatable Restraint																																								
S	2007	Canyon	Body	Vehicle Comm. Interface Module																																								
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																								
S	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																								
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
S	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
S	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
S	2007	Envoy	Chassis	Electronic Brake Control Module																																								
S	2007	Envoy	Body	Body Control Module																																								
S	2007	Envoy	Body	Digital Radio Receiver																																								
S	2007	Envoy	Body	Disc Player and Video Display																																								
S	2007	Envoy	Body	Driver Door Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2007	Envoy	Body	Driver Seat Module																																									
S	2007	Envoy	Body	Generator Battery Control Module																																									
S	2007	Envoy	Body	HVAC Control Module Auto					V	V																																			
S	2007	Envoy	Body	HVAC Control Module Manual						V																																			
S	2007	Envoy	Body	Instrument Panel Cluster																																									
S	2007	Envoy	Body	Lift Gate Module							V																																		
S	2007	Envoy	Body	Passenger Door Module																																									
S	2007	Envoy	Body	Passenger Presence System																																									
S	2007	Envoy	Body	Uplevel Radio																																									
S	2007	Envoy	Body	Navigation Radio																																									
S	2007	Envoy	Body	Rear Seat Audio																																									
S	2007	Envoy	Body	Supplemental Inflatable Restraint																																									
S	2007	Envoy	Body	Theft Deterrent Module																																									
S	2007	Envoy	Body	Vehicle Comm. Interface Module																																									
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																									
S	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																									
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																									
S	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																									
S	2008	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																									
S	2008	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																									
S	2008	Canyon	Body	Body Control Module																																									
S	2008	Canyon	Body	Digital Radio Receiver																																									
S	2008	Canyon	Body	Generator Battery Control Module																																									
S	2008	Canyon	Body	Instrument Panel Cluster																																									
S	2008	Canyon	Body	Passenger Presence System																																									
S	2008	Canyon	Body	Base Radio																																									
S	2008	Canyon	Body	Uplevel Radio																																									
S	2008	Canyon	Body	Supplemental Inflatable Restraint																																									
S	2008	Canyon	Body	Theft Deterrent Module																																									
S	2008	Canyon	Body	Vehicle Comm. Interface Module																																									
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																									
S	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																									
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																									
S	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																									
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																									
S	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																									
S	2008	Envoy	Chassis	Electronic Brake Control Module																																									
S	2008	Envoy	Body	Body Control Module																																									
S	2008	Envoy	Body	Digital Radio Receiver																																									
S	2008	Envoy	Body	Disc Player and Video Display																																									
S	2008	Envoy	Body	Driver Door Module																																									
S	2008	Envoy	Body	Driver Seat Module																																									
S	2008	Envoy	Body	Generator Battery Control Module																																									
S	2008	Envoy	Body	HVAC Control Module Auto					V	V																																			
S	2008	Envoy	Body	HVAC Control Module Manual						V																																			
S	2008	Envoy	Body	Instrument Panel Cluster																																									
S	2008	Envoy	Body	Lift Gate Module							V																																		
S	2008	Envoy	Body	Passenger Door Module																																									
S	2008	Envoy	Body	Passenger Presence System																																									
S	2008	Envoy	Body	Uplevel Radio																																									
S	2008	Envoy	Body	Navigation Radio																																									

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2008	Envoy	Body	Rear Seat Audio																																								
S	2008	Envoy	Body	Supplemental Inflatable Restraint																																								
S	2008	Envoy	Body	Theft Deterrent Module																																								
S	2008	Envoy	Body	Vehicle Comm. Interface Module																																								
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
S	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
S	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																								
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																								
S	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																								
S	2009	Canyon	Chassis	Electronic Brake Control Module																																								
S	2009	Canyon	Body	Body Control Module																																								
S	2009	Canyon	Body	Digital Radio Receiver																																								
S	2009	Canyon	Body	Generator Battery Control Module																																								
S	2009	Canyon	Body	Instrument Panel Cluster																																								
S	2009	Canyon	Body	Passenger Presence System																																								
S	2009	Canyon	Body	Base Radio																																								
S	2009	Canyon	Body	Uplevel Radio																																								
S	2009	Canyon	Body	Supplemental Inflatable Restraint																																								
S	2009	Canyon	Body	Theft Deterrent Module																																								
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
S	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Fuel Pump Control Module																																								
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
S	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Fuel Pump Control Module																																								
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
S	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Fuel Pump Control Module																																								
S	2009	Envoy	Chassis	Electronic Brake Control Module																																								
S	2009	Envoy	Body	Body Control Module																																								
S	2009	Envoy	Body	Digital Radio Receiver																																								
S	2009	Envoy	Body	Disc Player and Video Display																																								
S	2009	Envoy	Body	Driver Door Module																																								
S	2009	Envoy	Body	Driver Seat Module																																								
S	2009	Envoy	Body	Generator Battery Control Module																																								
S	2009	Envoy	Body	HVAC Control Module Auto					V	V																																		
S	2009	Envoy	Body	HVAC Control Module Manual						V																																		
S	2009	Envoy	Body	Instrument Panel Cluster																																								
S	2009	Envoy	Body	Lift Gate Module							V																																	
S	2009	Envoy	Body	Passenger Door Module																																								
S	2009	Envoy	Body	Passenger Presence System																																								
S	2009	Envoy	Body	Uplevel Radio																																								
S	2009	Envoy	Body	Navigation Radio																																								
S	2009	Envoy	Body	Rear Seat Audio																																								
S	2009	Envoy	Body	Supplemental Inflatable Restraint																																								
S	2009	Envoy	Body	Theft Deterrent Module																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
S	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
S	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																								
S	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																								
S	2010	ALL	Chassis	Electronic Brake Control Module																																								
S	2010	ALL	Body	Body Control Module																																								
S	2010	ALL	Body	Digital Radio Receiver																																								
S	2010	ALL	Body	Generator Battery Control Module																																								
S	2010	ALL	Body	Instument Panel Cluster																																								
S	2010	ALL	Body	Passenger Presence System																																								
S	2010	ALL	Body	Personal Audio Link Module																																								
S	2010	ALL	Body	Base Radio																																								
S	2010	ALL	Body	Uplevel Radio																																								
S	2010	ALL	Body	Supplemental Inflatable Restraint																																								
S	2010	ALL	Body	Theft Deterrent Module																																								
S	2010	ALL	Body	Vehicle Comm. Interface Module								V																																
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
T	2004	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																								
T	2004	Sonoma	Chassis	4WAL 3 Sensor																																								
T	2004	Sonoma	Chassis	Traction Assist (If Equipped)																																								
T	2004	Sonoma	Body	Body Control Module																																								
T	2004	Sonoma	Body	Instrument Panel Cluster																																								
T	2004	Sonoma	Body	Base Radio																																								
T	2004	Sonoma	Body	Uplevel Radio																																								
T	2004	Sonoma	Body	Supplemental Inflatable Restraint																																								
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																								
T	2004	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																								
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																								
T	2004	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																								
T	2004	Canyon	Chassis	ABS Without Traction Control																																								
T	2004	Canyon	Chassis	ABS With Traction Control																																								
T	2004	Canyon	Body	Body Control Module																																								
T	2004	Canyon	Body	Instrument Panel Cluster																																								
T	2004	Canyon	Body	OnStar																																								
T	2004	Canyon	Body	Base Radio																																								
T	2004	Canyon	Body	Uplevel Radio																																								
T	2004	Canyon	Body	Supplemental Inflatable Restraint																																								
T	2004	Canyon	Body	Instrument Panel Cluster																																								
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																								
T	2004	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																								
T	2004	Envoy	Chassis	ABS Without Traction Control																																								
T	2004	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
T	2004	Envoy	Chassis	Traction Assist (If Equipped)																																								
T	2004	Envoy	Body	Amplifier (Bose)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2004	Envoy	Body	Body Control Module																																								
T	2004	Envoy	Body	Driver Door Module																																								
T	2004	Envoy	Body	Driver Seat Module																																								
T	2004	Envoy	Body	Heating and Air Conditioning Auto					V																																			
T	2004	Envoy	Body	Heating and Air Conditioning Manual																																								
T	2004	Envoy	Body	Instrument Panel Cluster																																								
T	2004	Envoy	Body	Lift Gate Module																																								
T	2004	Envoy	Body	OnStar																																								
T	2004	Envoy	Body	Passenger Door Module																																								
T	2004	Envoy	Body	Uplevel Radio																																								
T	2004	Envoy	Body	Navigation Radio																																								
T	2004	Envoy	Body	Rear Seat Audio																																								
T	2004	Envoy	Body	Rear Seat Entertainment																																								
T	2004	Envoy	Body	Supplemental Inflatable Restraint																																								
T	2004	Envoy	Body	Vehicle Theft Deterrent																																								
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2004	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																								
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																								
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																								
T	2004	Envoy XL	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																								
T	2004	Envoy XL	Chassis	ABS Without Traction Control																																								
T	2004	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
T	2004	Envoy XL	Chassis	Traction Assist (If Equipped)																																								
T	2004	Envoy XL	Body	Amplifier (Bose)																																								
T	2004	Envoy XL	Body	Body Control Module																																								
T	2004	Envoy XL	Body	Driver Door Module																																								
T	2004	Envoy XL	Body	Driver Seat Module																																								
T	2004	Envoy XL	Body	Heating and Air Conditioning Auto					V																																			
T	2004	Envoy XL	Body	Heating and Air Conditioning Manual																																								
T	2004	Envoy XL	Body	Instrument Panel Cluster																																								
T	2004	Envoy XL	Body	Lift Gate Module																																								
T	2004	Envoy XL	Body	OnStar																																								
T	2004	Envoy XL	Body	Passenger Door Module																																								
T	2004	Envoy XL	Body	Uplevel Radio																																								
T	2004	Envoy XL	Body	Navigation Radio																																								
T	2004	Envoy XL	Body	Rear HVAC/RSA Auto																																								
T	2004	Envoy XL	Body	Rear HVAC Manual																																								
T	2004	Envoy XL	Body	Rear Seat Entertainment																																								
T	2004	Envoy XL	Body	Supplemental Inflatable Restraint																																								
T	2004	Envoy XL	Body	Vehicle Theft Deterrent																																								
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2004	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																								
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Engine Control Module																																								
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 Transmission Control Module																																								
T	2004	Envoy XUV	Powertrain	(P)5.3L V8 LM4 ATC Data Display																																								
T	2004	Envoy XUV	Chassis	ABS Without Traction Control																																								
T	2004	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
T	2004	Envoy XUV	Chassis	Traction Assist (If Equipped)																																								
T	2004	Envoy XUV	Body	Amplifier (Bose)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2004	Envoy XUV	Body	Body Control Module																																								
T	2004	Envoy XUV	Body	Driver Door Module																																								
T	2004	Envoy XUV	Body	Driver Seat Module																																								
T	2004	Envoy XUV	Body	Heating and Air Conditioning Auto					V																																			
T	2004	Envoy XUV	Body	Heating and Air Conditioning Manual																																								
T	2004	Envoy XUV	Body	Instrument Panel Cluster																																								
T	2004	Envoy XUV	Body	Lift Gate Module																																								
T	2004	Envoy XUV	Body	OnStar																																								
T	2004	Envoy XUV	Body	Passenger Door Module																																								
T	2004	Envoy XUV	Body	Uplevel Radio																																								
T	2004	Envoy XUV	Body	Navigation Radio																																								
T	2004	Envoy XUV	Body	Rear Seat Audio																																								
T	2004	Envoy XUV	Body	Rear Seat Entertainment																																								
T	2004	Envoy XUV	Body	Supplemental Inflatable Restraint																																								
T	2004	Envoy XUV	Body	Vehicle Theft Deterrent																																								
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
T	2004	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																								
T	2004	Jimmy	Chassis	4WAL 3 Sensor																																								
T	2004	Jimmy	Chassis	Traction Assist (If Equipped)																																								
T	2004	Jimmy	Body	Body Control Module																																								
T	2004	Jimmy	Body	Heating and Air Conditioning																																								
T	2004	Jimmy	Body	Instrument Panel Cluster																																								
T	2004	Jimmy	Body	Memory Seat Module																																								
T	2004	Jimmy	Body	Base Radio																																								
T	2004	Jimmy	Body	Uplevel Radio																																								
T	2004	Jimmy	Body	Supplemental Inflatable Restraint																																								
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																								
T	2005	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																								
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																								
T	2005	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																								
T	2005	Canyon	Chassis	ABS Without Traction Control																																								
T	2005	Canyon	Chassis	ABS With Traction Control																																								
T	2005	Canyon	Body	Body Control Module																																								
T	2005	Canyon	Body	Instrument Panel Cluster																																								
T	2005	Canyon	Body	Base Radio																																								
T	2005	Canyon	Body	Uplevel Radio																																								
T	2005	Canyon	Body	Supplemental Inflatable Restraint																																								
T	2005	Canyon	Body	Vehicle Comm. Interface Module																																								
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 1 Speed Active																																								
T	2005	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display 4 Button Selectable																																								
T	2005	Envoy	Chassis	ABS Without Traction Control																																								
T	2005	Envoy	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
T	2005	Envoy	Chassis	Traction Assist (If Equipped)																																								
T	2005	Envoy	Body	Body Control Module																																								
T	2005	Envoy	Body	Disc Player and Video Display																																								
T	2005	Envoy	Body	Driver Door Module																																								
T	2005	Envoy	Body	Driver Seat Module																																								
T	2005	Envoy	Body	Heating and Air Conditioning Auto					V																																			

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2005	Envoy	Body	Heating and Air Conditioning Manual																																								
T	2005	Envoy	Body	Instrument Panel Cluster																																								
T	2005	Envoy	Body	Lift Gate Module																																								
T	2005	Envoy	Body	Passenger Door Module																																								
T	2005	Envoy	Body	Passenger Presence System																																								
T	2005	Envoy	Body	Uplevel Radio																																								
T	2005	Envoy	Body	Navigation Radio																																								
T	2005	Envoy	Body	Rear Seat Audio																																								
T	2005	Envoy	Body	Supplemental Inflatable Restraint																																								
T	2005	Envoy	Body	Vehicle Comm. Interface Module																																								
T	2005	Envoy	Body	Vehicle Theft Deterrent																																								
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2005	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																								
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
T	2005	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																								
T	2005	Envoy XL	Chassis	ABS Without Traction Control																																								
T	2005	Envoy XL	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
T	2005	Envoy XL	Chassis	Traction Assist (If Equipped)																																								
T	2005	Envoy XL	Body	Body Control Module																																								
T	2005	Envoy XL	Body	Disc Player and Video Display																																								
T	2005	Envoy XL	Body	Driver Door Module																																								
T	2005	Envoy XL	Body	Driver Seat Module																																								
T	2005	Envoy XL	Body	Heating and Air Conditioning Auto					V																																			
T	2005	Envoy XL	Body	Heating and Air Conditioning Manual																																								
T	2005	Envoy XL	Body	Instrument Panel Cluster																																								
T	2005	Envoy XL	Body	Lift Gate Module																																								
T	2005	Envoy XL	Body	Passenger Door Module																																								
T	2005	Envoy XL	Body	Passenger Presence System																																								
T	2005	Envoy XL	Body	Uplevel Radio																																								
T	2005	Envoy XL	Body	Navigation Radio																																								
T	2005	Envoy XL	Body	Rear HVAC/RSA Auto																																								
T	2005	Envoy XL	Body	Rear HVAC Manual																																								
T	2005	Envoy XL	Body	Rear Seat Audio																																								
T	2005	Envoy XL	Body	Supplemental Inflatable Restraint																																								
T	2005	Envoy XL	Body	Vehicle Comm. Interface Module																																								
T	2005	Envoy XL	Body	Vehicle Theft Deterrent																																								
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2005	Envoy XUV	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																								
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
T	2005	Envoy XUV	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																								
T	2005	Envoy XUV	Chassis	ABS Without Traction Control																																								
T	2005	Envoy XUV	Chassis	ABS 4WAL 3 Sensor With Traction Control																																								
T	2005	Envoy XUV	Chassis	Traction Assist (If Equipped)																																								
T	2005	Envoy XUV	Body	Body Control Module																																								
T	2005	Envoy XUV	Body	Disc Player and Video Display																																								
T	2005	Envoy XUV	Body	Driver Door Module																																								
T	2005	Envoy XUV	Body	Driver Seat Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2005	Envoy XUV	Body	Heating and Air Conditioning Auto					V																																			
T	2005	Envoy XUV	Body	Heating and Air Conditioning Manual																																								
T	2005	Envoy XUV	Body	Instrument Panel Cluster																																								
T	2005	Envoy XUV	Body	Lift Gate Module																																								
T	2005	Envoy XUV	Body	Passenger Door Module																																								
T	2005	Envoy XUV	Body	Passenger Presence System																																								
T	2005	Envoy XUV	Body	Uplevel Radio																																								
T	2005	Envoy XUV	Body	Navigation Radio																																								
T	2005	Envoy XUV	Body	Rear Seat Audio																																								
T	2005	Envoy XUV	Body	Supplemental Inflatable Restraint																																								
T	2005	Envoy XUV	Body	Vehicle Comm. Interface Module																																								
T	2005	Envoy XUV	Body	Vehicle Theft Deterrent																																								
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
T	2005	Jimmy	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																								
T	2005	Jimmy	Chassis	4WAL 3 Sensor																																								
T	2005	Jimmy	Chassis	Traction Assist (If Equipped)																																								
T	2005	Jimmy	Body	Body Control Module																																								
T	2005	Jimmy	Body	Heating and Air Conditioning																																								
T	2005	Jimmy	Body	Instrument Panel Cluster																																								
T	2005	Jimmy	Body	Memory Seat Module																																								
T	2005	Jimmy	Body	Base Radio																																								
T	2005	Jimmy	Body	Uplevel Radio																																								
T	2005	Jimmy	Body	Supplemental Inflatable Restraint																																								
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
T	2005	Sonoma	Powertrain	(X)4.3L V6 LU3 ATC Data Display																																								
T	2005	Sonoma	Chassis	4WAL 3 Sensor																																								
T	2005	Sonoma	Chassis	Traction Assist (If Equipped)																																								
T	2005	Sonoma	Body	Body Control Module																																								
T	2005	Sonoma	Body	Instrument Panel Cluster																																								
T	2005	Sonoma	Body	Base Radio																																								
T	2005	Sonoma	Body	Uplevel Radio																																								
T	2005	Sonoma	Body	Supplemental Inflatable Restraint																																								
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Engine Control Module																																								
T	2006	Canyon	Powertrain	(8)2.8L L4 LK5 Transmission Control Module																																								
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Engine Control Module																																								
T	2006	Canyon	Powertrain	(6)3.5L L5 L52 Transmission Control Module																																								
T	2006	Canyon	Chassis	ABS Without Traction Control																																								
T	2006	Canyon	Chassis	ABS With Traction Control																																								
T	2006	Canyon	Body	Body Control Module																																								
T	2006	Canyon	Body	Instrument Panel Cluster																																								
T	2006	Canyon	Body	Passenger Presence System																																								
T	2006	Canyon	Body	Base Radio																																								
T	2006	Canyon	Body	Uplevel Radio																																								
T	2006	Canyon	Body	Supplemental Inflatable Restraint																																								
T	2006	Canyon	Body	Vehicle Comm. Interface Module																																								
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2006	Envoy	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																								
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
T	2006	Envoy	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																								
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
T	2006	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
T	2006	Envoy	Chassis	ABS/TCS/VSES																																								
T	2006	Envoy	Chassis	Tire Pressure Monitor																																								
T	2006	Envoy	Body	Body Control Module																																								
T	2006	Envoy	Body	Disc Player and Video Display																																								
T	2006	Envoy	Body	Driver Door Module																																								
T	2006	Envoy	Body	Driver Seat Module																																								
T	2006	Envoy	Body	Heating and Air Conditioning Auto					V																																			
T	2006	Envoy	Body	Heating and Air Conditioning Manual																																								
T	2006	Envoy	Body	Instrument Panel Cluster																																								
T	2006	Envoy	Body	Lift Gate Module																																								
T	2006	Envoy	Body	Passenger Door Module																																								
T	2006	Envoy	Body	Passenger Presence System																																								
T	2006	Envoy	Body	Uplevel Radio																																								
T	2006	Envoy	Body	Navigation Radio																																								
T	2006	Envoy	Body	Rear Seat Audio																																								
T	2006	Envoy	Body	Supplemental Inflatable Restraint																																								
T	2006	Envoy	Body	Vehicle Theft Deterrent																																								
T	2006	Envoy	Body	Vehicle Comm. Interface Module																																								
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2006	Envoy XL	Powertrain	(S)4.2L L6 LL8 ATC Data Display																																								
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
T	2006	Envoy XL	Powertrain	(M)5.3L V8 LH6 ATC Data Display																																								
T	2006	Envoy XL	Chassis	ABS/TCS/VSES																																								
T	2006	Envoy XL	Body	Body Control Module																																								
T	2006	Envoy XL	Body	Disc Player and Video Display																																								
T	2006	Envoy XL	Body	Driver Door Module																																								
T	2006	Envoy XL	Body	Driver Seat Module																																								
T	2006	Envoy XL	Body	Heating and Air Conditioning Auto					V																																			
T	2006	Envoy XL	Body	Heating and Air Conditioning Manual																																								
T	2006	Envoy XL	Body	Instrument Panel Cluster																																								
T	2006	Envoy XL	Body	Lift Gate Module																																								
T	2006	Envoy XL	Body	Passenger Door Module																																								
T	2006	Envoy XL	Body	Passenger Presence System																																								
T	2006	Envoy XL	Body	Uplevel Radio																																								
T	2006	Envoy XL	Body	Navigation Radio																																								
T	2006	Envoy XL	Body	Rear HVAC/RSA Auto																																								
T	2006	Envoy XL	Body	Rear HVAC Manual																																								
T	2006	Envoy XL	Body	Rear Seat Audio																																								
T	2006	Envoy XL	Body	Supplemental Inflatable Restraint																																								
T	2006	Envoy XL	Body	Vehicle Theft Deterrent																																								
T	2006	Envoy XL	Body	Vehicle Comm. Interface Module																																								
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
T	2007	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																								
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																									
T	2007	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																									
T	2007	Canyon	Chassis	Electronic Brake Control Module Without Traction Control																																									
T	2007	Canyon	Chassis	Electronic Brake Control Module With Traction Control																																									
T	2007	Canyon	Body	Body Control Module																																									
T	2007	Canyon	Body	Digital Radio Receiver																																									
T	2007	Canyon	Body	Generator Battery Control Module																																									
T	2007	Canyon	Body	Instrument Panel Cluster																																									
T	2007	Canyon	Body	Passenger Presence System																																									
T	2007	Canyon	Body	Base Radio																																									
T	2007	Canyon	Body	Uplevel Radio																																									
T	2007	Canyon	Body	Supplemental Inflatable Restraint																																									
T	2007	Canyon	Body	Vehicle Comm. Interface Module																																									
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																									
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																									
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																									
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Engine Control Module																																									
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transmission Control Module																																									
T	2007	Envoy	Powertrain	(S)4.2L L6 LL8 Japan Transfer Case Control Module																																									
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																									
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																									
T	2007	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																									
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																									
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																									
T	2007	Envoy	Powertrain	(H)6.0L V8 LS2 Transfer Case Control Module																																									
T	2007	Envoy	Chassis	Electronic Brake Control Module																																									
T	2007	Envoy	Body	Body Control Module																																									
T	2007	Envoy	Body	Digital Radio Receiver																																									
T	2007	Envoy	Body	Disc Player and Video Display																																									
T	2007	Envoy	Body	Driver Door Module																																									
T	2007	Envoy	Body	Driver Seat Module																																									
T	2007	Envoy	Body	Generator Battery Control Module																																									
T	2007	Envoy	Body	HVAC Control Module Auto					V	V																																			
T	2007	Envoy	Body	HVAC Control Module Manual						V																																			
T	2007	Envoy	Body	Instrument Panel Cluster																																									
T	2007	Envoy	Body	Lift Gate Module							V																																		
T	2007	Envoy	Body	Passenger Door Module																																									
T	2007	Envoy	Body	Passenger Presence System																																									
T	2007	Envoy	Body	Uplevel Radio																																									
T	2007	Envoy	Body	Navigation Radio																																									
T	2007	Envoy	Body	Rear Seat Audio																																									
T	2007	Envoy	Body	Supplemental Inflatable Restraint																																									
T	2007	Envoy	Body	Theft Deterrent Module																																									
T	2007	Envoy	Body	Vehicle Comm. Interface Module																																									
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																									
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																									
T	2008	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																									
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																									
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																									
T	2008	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																									
T	2008	Canyon	Chassis	Electronic Brake Control Module																																									

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Thefflock LED
T	2008	Canyon	Body	Body Control Module																																								
T	2008	Canyon	Body	Digital Radio Receiver																																								
T	2008	Canyon	Body	Generator Battery Control Module																																								
T	2008	Canyon	Body	Instrument Panel Cluster																																								
T	2008	Canyon	Body	Passenger Presence System																																								
T	2008	Canyon	Body	Base Radio																																								
T	2008	Canyon	Body	Uplevel Radio																																								
T	2008	Canyon	Body	Supplemental Inflatable Restraint																																								
T	2008	Canyon	Body	Theft Deterrent Module																																								
T	2008	Canyon	Body	Vehicle Comm. Interface Module																																								
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2008	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																								
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
T	2008	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																								
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
T	2008	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
T	2008	Envoy	Chassis	Electronic Brake Control Module																																								
T	2008	Envoy	Body	Body Control Module																																								
T	2008	Envoy	Body	Digital Radio Receiver																																								
T	2008	Envoy	Body	Disc Player and Video Display																																								
T	2008	Envoy	Body	Driver Door Module																																								
T	2008	Envoy	Body	Driver Seat Module																																								
T	2008	Envoy	Body	Generator Battery Control Module																																								
T	2008	Envoy	Body	HVAC Control Module Auto					V	V																																		
T	2008	Envoy	Body	HVAC Control Module Manual						V																																		
T	2008	Envoy	Body	Instrument Panel Cluster																																								
T	2008	Envoy	Body	Lift Gate Module							V																																	
T	2008	Envoy	Body	Passenger Door Module																																								
T	2008	Envoy	Body	Passenger Presence System																																								
T	2008	Envoy	Body	Uplevel Radio																																								
T	2008	Envoy	Body	Navigation Radio																																								
T	2008	Envoy	Body	Rear Seat Audio																																								
T	2008	Envoy	Body	Supplemental Inflatable Restraint																																								
T	2008	Envoy	Body	Theft Deterrent Module																																								
T	2008	Envoy	Body	Vehicle Comm. Interface Module																																								
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
T	2009	Canyon	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																								
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
T	2009	Canyon	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																								
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Engine Control Module																																								
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transmission Control Module																																								
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Fuel Pump Control Module																																								
T	2009	Canyon	Powertrain	(L)5.3L V8 LH8 Transfer Case Control Module																																								
T	2009	Canyon	Chassis	Electronic Brake Control Module																																								
T	2009	Canyon	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
T	2009	Canyon	Body	Digital Radio Receiver																																								
T	2009	Canyon	Body	Generator Battery Control Module																																								
T	2009	Canyon	Body	Instrument Panel Cluster																																								
T	2009	Canyon	Body	Passenger Presence System																																								
T	2009	Canyon	Body	Base Radio																																								
T	2009	Canyon	Body	Uplevel Radio																																								
T	2009	Canyon	Body	Supplemental Inflatable Restraint																																								
T	2009	Canyon	Body	Theft Deterrent Module																																								
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Engine Control Module																																								
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transmission Control Module																																								
T	2009	Envoy	Powertrain	(S)4.2L L6 LL8 Transfer Case Control Module																																								
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Engine Control Module																																								
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transmission Control Module																																								
T	2009	Envoy	Powertrain	(M)5.3L V8 LH6 Transfer Case Control Module																																								
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Engine Control Module																																								
T	2009	Envoy	Powertrain	(H)6.0L V8 LS2 Transmission Control Module																																								
T	2009	Envoy	Chassis	Electronic Brake Control Module																																								
T	2009	Envoy	Body	Body Control Module																																								
T	2009	Envoy	Body	Digital Radio Receiver																																								
T	2009	Envoy	Body	Disc Player and Video Display																																								
T	2009	Envoy	Body	Driver Door Module																																								
T	2009	Envoy	Body	Driver Seat Module																																								
T	2009	Envoy	Body	Generator Battery Control Module																																								
T	2009	Envoy	Body	HVAC Control Module Auto					V	V																																		
T	2009	Envoy	Body	HVAC Control Module Manual						V																																		
T	2009	Envoy	Body	Instrument Panel Cluster																																								
T	2009	Envoy	Body	Lift Gate Module							V																																	
T	2009	Envoy	Body	Passenger Door Module																																								
T	2009	Envoy	Body	Passenger Presence System																																								
T	2009	Envoy	Body	Uplevel Radio																																								
T	2009	Envoy	Body	Navigation Radio																																								
T	2009	Envoy	Body	Rear Seat Audio																																								
T	2009	Envoy	Body	Supplemental Inflatable Restraint																																								
T	2009	Envoy	Body	Theft Deterrent Module																																								
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
T	2010	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																								
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
T	2010	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																								
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																								
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																								
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																								
T	2010	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																								
T	2010	ALL	Chassis	Electronic Brake Control Module																																								
T	2010	ALL	Body	Body Control Module																																								
T	2010	ALL	Body	Digital Radio Receiver																																								
T	2010	ALL	Body	Generator Battery Control Module																																								
T	2010	ALL	Body	Instrument Panel Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Thefflock LED
T	2010	ALL	Body	Passenger Presence System																																								
T	2010	ALL	Body	Personal Audio Link Module																																								
T	2010	ALL	Body	Base Radio																																								
T	2010	ALL	Body	Uplevel Radio																																								
T	2010	ALL	Body	Supplemental Inflatable Restraint																																								
T	2010	ALL	Body	Theft Deterrent Module																																								
T	2010	ALL	Body	Vehicle Comm. Interface Module								V																																
V	2007	ALL	Powertrain	Engine Control Module																																								
V	2007	ALL	Powertrain	Rear Drive System																																								
V	2007	ALL	Powertrain	Transmission Control Module																																								
V	2007	ALL	Chassis	Electronic Brake Control Module																																								
V	2007	ALL	Body	Body Control Module																																								
V	2007	ALL	Body	Digital Radio Receiver																																								
V	2007	ALL	Body	Driver Door Switch																																								
V	2007	ALL	Body	Head Up Display																																								
V	2007	ALL	Body	Heated Seat Module																																								
V	2007	ALL	Body	HVAC Control Module Auto																																								
V	2007	ALL	Body	HVAC Control Module Manual																																								
V	2007	ALL	Body	Instrument Panel Cluster																																								
V	2007	ALL	Body	Lift Gate Module																																								
V	2007	ALL	Body	Park Assist Module																																								
V	2007	ALL	Body	Passenger Door Switch																																								
V	2007	ALL	Body	Passenger Presence System																																								
V	2007	ALL	Body	Radio																																								
V	2007	ALL	Body	Rear HVAC/RSA																																								
V	2007	ALL	Body	Rollover Sensor																																								
V	2007	ALL	Body	Supplemental Inflatable Restraint																																								
V	2007	ALL	Body	Theft Deterrent Module																																								
V	2008	ALL	Powertrain	Engine Control Module																																								
V	2008	ALL	Powertrain	Rear Drive System																																								
V	2008	ALL	Powertrain	Transmission Control Module																																								
V	2008	ALL	Chassis	Electronic Brake Control Module																																								
V	2008	ALL	Body	Body Control Module																																								
V	2008	ALL	Body	Digital Radio Receiver																																								
V	2008	ALL	Body	Driver Door Switch																																								
V	2008	ALL	Body	Head Up Display																																								
V	2008	ALL	Body	Heated Seat Module																																								
V	2008	ALL	Body	HVAC Control Module Auto																																								
V	2008	ALL	Body	HVAC Control Module Manual																																								
V	2008	ALL	Body	Instrument Panel Cluster																																								
V	2008	ALL	Body	Lift Gate Module																																								
V	2008	ALL	Body	Park Assist Module																																								
V	2008	ALL	Body	Passenger Door Switch																																								
V	2008	ALL	Body	Passenger Presence System																																								
V	2008	ALL	Body	Radio																																								
V	2008	ALL	Body	Rear HVAC/RSA																																								
V	2008	ALL	Body	Rollover Sensor																																								
V	2008	ALL	Body	Supplemental Inflatable Restraint																																								
V	2008	ALL	Body	Theft Deterrent Module																																								
V	2009	ALL	Powertrain	Engine Control Module																																								
V	2009	ALL	Powertrain	Fuel Pump Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
V	2009	ALL	Powertrain	Rear Drive System																																								
V	2009	ALL	Powertrain	Transmission Control Module																																								
V	2009	ALL	Chassis	Electronic Brake Control Module																																								
V	2009	ALL	Body	Body Control Module																																								
V	2009	ALL	Body	Digital Radio Receiver																																								
V	2009	ALL	Body	Driver Door Switch				V																																				
V	2009	ALL	Body	Head Up Display																																								
V	2009	ALL	Body	Heated Seat Module																																								
V	2009	ALL	Body	HVAC Control Module Auto																																								
V	2009	ALL	Body	HVAC Control Module Manual																																								
V	2009	ALL	Body	Instrument Panel Cluster																																								
V	2009	ALL	Body	Lift Gate Module																																								
V	2009	ALL	Body	Park Assist Module																																								
V	2009	ALL	Body	Passenger Door Switch				V																																				
V	2009	ALL	Body	Passenger Presence System																																								
V	2009	ALL	Body	Radio																																								
V	2009	ALL	Body	Rear HVAC/RSA																																								
V	2009	ALL	Body	Rollover Sensor																																								
V	2009	ALL	Body	Supplemental Inflatable Restraint																																								
V	2009	ALL	Body	Theft Deterrent Module																																								
V	2010	ALL	Powertrain	Engine Control Module																																								
V	2010	ALL	Powertrain	Fuel Pump Control Module																																								
V	2010	ALL	Powertrain	Rear Drive System																																								
V	2010	ALL	Powertrain	Transmission Control Module																																								
V	2010	ALL	Chassis	Electronic Brake Control Module																																								
V	2010	ALL	Body	Body Control Module																																								
V	2010	ALL	Body	Digital Radio Receiver																																								
V	2010	ALL	Body	Driver Door Switch				V																																				
V	2010	ALL	Body	Head Up Display																																								
V	2010	ALL	Body	Heated Seat Module																																								
V	2010	ALL	Body	HVAC Control Module Auto																																								
V	2010	ALL	Body	HVAC Control Module Manual																																								
V	2010	ALL	Body	Instrument Panel Cluster																																								
V	2010	ALL	Body	Lift Gate Module																																								
V	2010	ALL	Body	Park Assist Module																																								
V	2010	ALL	Body	Passenger Door Switch				V																																				
V	2010	ALL	Body	Passenger Presence System																																								
V	2010	ALL	Body	Radio																																								
V	2010	ALL	Body	Rear HVAC/RSA																																								
V	2010	ALL	Body	Supplemental Inflatable Restraint																																								
V	2010	ALL	Body	Theft Deterrent Module																																								
V	2011	ALL	Powertrain	Engine Control Module																																								
V	2011	ALL	Powertrain	Fuel Pump Control Module																																								
V	2011	ALL	Powertrain	Rear Drive System																																								
V	2011	ALL	Powertrain	Transmission Control Module																																								
V	2011	ALL	Chassis	Electronic Brake Control Module																																								
V	2011	ALL	Body	Body Control Module																																								
V	2011	ALL	Body	Digital Radio Receiver																																								
V	2011	ALL	Body	Driver Door Switch				V																																				
V	2011	ALL	Body	Head Up Display																																								
V	2011	ALL	Body	Heated Seat Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
V	2011	ALL	Body	HVAC Control Module Auto																																								
V	2011	ALL	Body	HVAC Control Module Manual																																								
V	2011	ALL	Body	Instrument Panel Cluster																																								
V	2011	ALL	Body	Lift Gate Module																																								
V	2011	ALL	Body	Park Assist Module																																								
V	2011	ALL	Body	Passenger Door Switch				V																																				
V	2011	ALL	Body	Passenger Presence System																																								
V	2011	ALL	Body	Radio																																								
V	2011	ALL	Body	Rear HVAC/RSA																																								
V	2011	ALL	Body	Supplemental Inflatable Restraint																																								
V	2011	ALL	Body	Theft Deterrent Module																																								
V	2012	ALL	Powertrain	Engine Control Module																																								
V	2012	ALL	Powertrain	Fuel Pump Control Module																																								
V	2012	ALL	Powertrain	Rear Drive System																																								
V	2012	ALL	Powertrain	Transmission Control Module																																								
V	2012	ALL	Chassis	Electronic Brake Control Module																																								
V	2012	ALL	Body	Body Control Module																																								
V	2012	ALL	Body	Digital Radio Receiver																																								
V	2012	ALL	Body	Driver Door Switch				V																																				
V	2012	ALL	Body	Head Up Display																																								
V	2012	ALL	Body	Heated Seat Module																																								
V	2012	ALL	Body	HVAC Control Module Auto																																								
V	2012	ALL	Body	HVAC Control Module Manual																																								
V	2012	ALL	Body	Instrument Panel Cluster																																								
V	2012	ALL	Body	Lift Gate Module																																								
V	2012	ALL	Body	Park Assist Module																																								
V	2012	ALL	Body	Passenger Door Switch				V																																				
V	2012	ALL	Body	Passenger Presence System																																								
V	2012	ALL	Body	Radio																																								
V	2012	ALL	Body	Rear HVAC/RSA																																								
V	2012	ALL	Body	Supplemental Inflatable Restraint																																								
V	2012	ALL	Body	Theft Deterrent Module																																								
V	2013	ALL	Powertrain	Engine Control Module																																								
V	2013	ALL	Powertrain	Fuel Pump Control Module																																								
V	2013	ALL	Powertrain	Rear Drive System																																								
V	2013	ALL	Powertrain	Transmission Control Module																																								
V	2013	ALL	Chassis	Electronic Brake Control Module																																								
V	2013	ALL	Body	Body Control Module																																								
V	2013	ALL	Body	Digital Radio Receiver																																								
V	2013	ALL	Body	Driver Door Switch				V																																				
V	2013	ALL	Body	Head Up Display																																								
V	2013	ALL	Body	Heated Seat Module																																								
V	2013	ALL	Body	HVAC Control Module Auto																																								
V	2013	ALL	Body	HVAC Control Module Manual																																								
V	2013	ALL	Body	Instrument Panel Cluster																																								
V	2013	ALL	Body	Left Side Object Detection Module																																								
V	2013	ALL	Body	Lift Gate Module																																								
V	2013	ALL	Body	Park Assist Module																																								
V	2013	ALL	Body	Passenger Door Switch				V																																				
V	2013	ALL	Body	Passenger Presence System																																								
V	2013	ALL	Body	Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
V	2013	ALL	Body	Rear HVAC/RSA																																								
V	2013	ALL	Body	Right Side Object Detection Module																																								
V	2013	ALL	Body	Supplemental Inflatable Restraint																																								
V	2013	ALL	Body	Theft Deterrent Module																																								
V	2014	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																								
V	2014	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
V	2014	Acadia	Powertrain	Chassis Control Module																																								
V	2014	Acadia	Powertrain	Rear Differential Clutch Control Module																																								
V	2014	Acadia	Chassis	Electronic Brake Control Module																																								
V	2014	Acadia	Body	Body Control Module Mechanical Liftgate																																								
V	2014	Acadia	Body	Body Control Module Power Liftgate (TB5)																																								
V	2014	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
V	2014	Acadia	Body	Passenger Presence Module																																								
V	2014	Acadia	Body	Instrument Cluster																																								
V	2014	Acadia	Body	Head-Up Display Module																																								
V	2014	Acadia	Body	Radio																																								
V	2014	Acadia	Body	Rear Audio Control Module																																								
V	2014	Acadia	Body	Digital Radio Receiver Control Module																																								
V	2014	Acadia	Body	Personal Audio Link Control Module																																								
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 9																																								
V	2014	Acadia	Body	Telematics Communication Interface Control Module Version 10																																								
V	2014	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																								
V	2014	Acadia	Body	HVAC Manual Control Single Zone (C67)																																								
V	2014	Acadia	Body	Driver Door Switch Panel Control Module																																								
V	2014	Acadia	Body	Passenger Door Switch Panel Control Module																																								
V	2014	Acadia	Body	Liftgate Control Module																																								
V	2014	Acadia	Body	Seat Memory Control Module																																								
V	2014	Acadia	Body	Front Seat Heating Control Module																																								
V	2014	Acadia	Body	Right Side Object Detection Control Module																																								
V	2014	Acadia	Body	Left Side Object Detection Control Module																																								
V	2014	Acadia	Body	Remote Control Door Lock Receiver																																								
V	2014	Acadia	Body	Parking Assist Control Module																																								
V	2014	Acadia	Body	Frontview Camera Module																																								
V	2014	Acadia	Body	Theft Deterrent Module																																								
V	2015	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																								
V	2015	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
V	2015	Acadia	Powertrain	Rear Differential Clutch Control Module																																								
V	2015	Acadia	Chassis	Electronic Brake Control Module																																								
V	2015	Acadia	Body	Body Control Module Mechanical Liftgate																																								
V	2015	Acadia	Body	Body Control Module Power Liftgate (TB5)																																								
V	2015	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
V	2015	Acadia	Body	Passenger Presence Module																																								
V	2015	Acadia	Body	Instrument Cluster																																								
V	2015	Acadia	Body	Head-Up Display Module																																								
V	2015	Acadia	Body	Radio																																								
V	2015	Acadia	Body	Rear Audio Control Module																																								
V	2015	Acadia	Body	Digital Radio Receiver Control Module																																								
V	2015	Acadia	Body	Personal Audio Link Control Module																																								
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 9																																								
V	2015	Acadia	Body	Telematics Communication Interface Control Module Version 10																																								
V	2015	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
V	2015	Acadia	Body	HVAC Manual Control Single Zone (C67)																																								
V	2015	Acadia	Body	Driver Door Switch Panel Control Module																																								
V	2015	Acadia	Body	Passenger Door Switch Panel Control Module																																								
V	2015	Acadia	Body	Liftgate Control Module																																								
V	2015	Acadia	Body	Seat Memory Control Module																																								
V	2015	Acadia	Body	Front Seat Heating Control Module																																								
V	2015	Acadia	Body	Right Side Object Detection Control Module																																								
V	2015	Acadia	Body	Left Side Object Detection Control Module																																								
V	2015	Acadia	Body	Remote Control Door Lock Receiver																																								
V	2015	Acadia	Body	Parking Assist Control Module																																								
V	2015	Acadia	Body	Frontview Camera Module																																								
V	2015	Acadia	Body	Theft Deterrent Module																																								
V	2016	Acadia	Powertrain	(D) 3.6L LLT Engine Control Module																																								
V	2016	Acadia	Powertrain	(D) 3.6L LLT Transmission Control Module																																								
V	2016	Acadia	Powertrain	Rear Differential Clutch Control Module																																								
V	2016	Acadia	Chassis	Electronic Brake Control Module																																								
V	2016	Acadia	Body	Body Control Module Mechanical Liftgate																																								
V	2016	Acadia	Body	Body Control Module Power Liftgate (TB5)																																								
V	2016	Acadia	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
V	2016	Acadia	Body	Passenger Presence Module																																								
V	2016	Acadia	Body	Instrument Cluster																																								
V	2016	Acadia	Body	Head-Up Display Module																																								
V	2016	Acadia	Body	Radio																																								
V	2016	Acadia	Body	Rear Audio Control Module																																								
V	2016	Acadia	Body	Digital Radio Receiver Control Module																																								
V	2016	Acadia	Body	Personal Audio Link Control Module																																								
V	2016	Acadia	Body	Telematics Communication Interface Control Module																																								
V	2016	Acadia	Body	HVAC Auto Control Dual Zone (CJ2)																																								
V	2016	Acadia	Body	HVAC Manual Control Single Zone (C67)																																								
V	2016	Acadia	Body	Driver Door Switch Panel Control Module																																								
V	2016	Acadia	Body	Passenger Door Switch Panel Control Module																																								
V	2016	Acadia	Body	Liftgate Control Module																																								
V	2016	Acadia	Body	Seat Memory Control Module																																								
V	2016	Acadia	Body	Front Seat Heating Control Module																																								
V	2016	Acadia	Body	Right Side Object Detection Control Module																																								
V	2016	Acadia	Body	Left Side Object Detection Control Module																																								
V	2016	Acadia	Body	Remote Control Door Lock Receiver																																								
V	2016	Acadia	Body	Parking Assist Control Module																																								
V	2016	Acadia	Body	Frontview Camera Module																																								
V	2016	Acadia	Body	Theft Deterrent Module																																								
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
1	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
1	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
1	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
1	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
1	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
1	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																								
1	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																								
1	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								
1	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																								
1	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																								
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
1	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
1	2011	Sierra	Chassis	Electronic Suspension Control																																								
1	2011	Sierra	Chassis	Trailer Brake Control Module																																								
1	2011	Sierra	Body	Amplifier (Bose)																																								
1	2011	Sierra	Body	Body Control Module																																								
1	2011	Sierra	Body	Body Control Module (aux.)																																								
1	2011	Sierra	Body	Digital Radio Receiver																																								
1	2011	Sierra	Body	Driver Door Switch																																								
1	2011	Sierra	Body	HVAC Control Module Auto																																								
1	2011	Sierra	Body	HVAC Control Module Manual																																								
1	2011	Sierra	Body	Instrument Panel Cluster																																								
1	2011	Sierra	Body	Memory Seat Module																																								
1	2011	Sierra	Body	Park Assist Module																																								
1	2011	Sierra	Body	Passenger Door Switch																																								
1	2011	Sierra	Body	Passenger Presence System																																								
1	2011	Sierra	Body	Radio																																								
1	2011	Sierra	Body	Rear Heated Seat Module																																								
1	2011	Sierra	Body	Rear HVAC/RSA																																								
1	2011	Sierra	Body	Supplemental Inflatable Restraint																																								
1	2011	Sierra	Body	Theft Deterrent Module																																								
1	2011	Sierra Hybrid	Powertrain	Engine Control Module																																								
1	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																								
1	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																								
1	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																								
1	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																								
1	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																								
1	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																								
1	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																								
1	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																								
1	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																								
1	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																								
1	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																								
1	2011	Sierra Hybrid	Body	Amplifier (Bose)																																								
1	2011	Sierra Hybrid	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																								
1	2011	Sierra Hybrid	Body	Digital Radio Receiver																																								
1	2011	Sierra Hybrid	Body	Driver Door Switch																																								
1	2011	Sierra Hybrid	Body	Heated Seat Module																																								
1	2011	Sierra Hybrid	Body	HVAC Control Module																																								
1	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																								
1	2011	Sierra Hybrid	Body	Park Assist Module																																								
1	2011	Sierra Hybrid	Body	Passenger Door Switch																																								
1	2011	Sierra Hybrid	Body	Passenger Presence System																																								
1	2011	Sierra Hybrid	Body	Radio																																								
1	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																								
1	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																								
1	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																								
1	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																								
1	2011	Sierra Hybrid	Body	Theft Deterrent Module																																								
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
1	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
1	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
1	2011	Yukon	Chassis	Electronic Brake Control Module																																								
1	2011	Yukon	Chassis	Electronic Suspension Control																																								
1	2011	Yukon	Chassis	Trailer Brake Control Module																																								
1	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																								
1	2011	Yukon	Body	Amplifier (Bose)																																								
1	2011	Yukon	Body	Assist Step Controller																																								
1	2011	Yukon	Body	Body Control Module																																								
1	2011	Yukon	Body	Body Control Module (aux.)																																								
1	2011	Yukon	Body	Digital Radio Receiver																																								
1	2011	Yukon	Body	Driver Door Switch																																								
1	2011	Yukon	Body	HVAC Control Module Auto																																								
1	2011	Yukon	Body	HVAC Control Module Manual																																								
1	2011	Yukon	Body	Instrument Panel Cluster																																								
1	2011	Yukon	Body	Left Side Object Detection Module																																								
1	2011	Yukon	Body	Lift Gate Module																																								
1	2011	Yukon	Body	Memory Seat Module																																								
1	2011	Yukon	Body	Park Assist Module																																								
1	2011	Yukon	Body	Passenger Door Switch																																								
1	2011	Yukon	Body	Passenger Presence System																																								
1	2011	Yukon	Body	Radio																																								
1	2011	Yukon	Body	Rear Heated Seat Module																																								
1	2011	Yukon	Body	Rear HVAC/RSA																																								
1	2011	Yukon	Body	Right Side Object Detection Module																																								
1	2011	Yukon	Body	Supplemental Inflatable Restraint																																								
1	2011	Yukon	Body	Theft Deterrent Module																																								
1	2011	Yukon Hybrid	Powertrain	Engine Control Module																																								
1	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																								
1	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																								
1	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																								
1	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																								
1	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																								
1	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																								
1	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																								
1	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																								
1	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																								
1	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																								
1	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																								
1	2011	Yukon Hybrid	Body	Amplifier (Bose)																																								
1	2011	Yukon Hybrid	Body	Assist Step Controller																																								
1	2011	Yukon Hybrid	Body	Body Control Module																																								
1	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																								
1	2011	Yukon Hybrid	Body	Digital Radio Receiver																																								
1	2011	Yukon Hybrid	Body	Driver Door Switch																																								
1	2011	Yukon Hybrid	Body	Heated Seat Module																																								
1	2011	Yukon Hybrid	Body	HVAC Control Module																																								
1	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																								
1	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																								
1	2011	Yukon Hybrid	Body	Lift Gate Module																																								
1	2011	Yukon Hybrid	Body	Park Assist Module																																								
1	2011	Yukon Hybrid	Body	Passenger Door Switch																																								
1	2011	Yukon Hybrid	Body	Passenger Presence System																																								
1	2011	Yukon Hybrid	Body	Radio																																								
1	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																								
1	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																								
1	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																								
1	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																								
1	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																								
1	2011	Yukon Hybrid	Body	Theft Deterrent Module																																								
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
1	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
1	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
1	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
1	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
1	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																								
1	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																								
1	2011	Yukon XL	Chassis	Electronic Suspension Control																																								
1	2011	Yukon XL	Chassis	Trailer Brake Control Module																																								
1	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																								
1	2011	Yukon XL	Body	Amplifier (Bose)																																								
1	2011	Yukon XL	Body	Assist Step Controller																																								
1	2011	Yukon XL	Body	Body Control Module																																								
1	2011	Yukon XL	Body	Body Control Module (aux.)																																								
1	2011	Yukon XL	Body	Digital Radio Receiver																																								
1	2011	Yukon XL	Body	Driver Door Switch																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2011	Yukon XL	Body	HVAC Control Module Auto																																								
1	2011	Yukon XL	Body	HVAC Control Module Manual																																								
1	2011	Yukon XL	Body	Instrument Panel Cluster																																								
1	2011	Yukon XL	Body	Left Side Object Detection Module																																								
1	2011	Yukon XL	Body	Lift Gate Module																																								
1	2011	Yukon XL	Body	Memory Seat Module																																								
1	2011	Yukon XL	Body	Park Assist Module																																								
1	2011	Yukon XL	Body	Passenger Door Switch																																								
1	2011	Yukon XL	Body	Passenger Presence System																																								
1	2011	Yukon XL	Body	Radio																																								
1	2011	Yukon XL	Body	Rear Heated Seat Module																																								
1	2011	Yukon XL	Body	Rear HVAC/RSA																																								
1	2011	Yukon XL	Body	Right Side Object Detection Module																																								
1	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																								
1	2011	Yukon XL	Body	Theft Deterrent Module																																								
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
1	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
1	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
1	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
1	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
1	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
1	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																								
1	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																								
1	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								
1	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																								
1	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																								
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
1	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
1	2012	Sierra	Chassis	Electronic Suspension Control																																								
1	2012	Sierra	Chassis	Trailer Brake Control Module																																								
1	2012	Sierra	Body	Amplifier (Bose)																																								
1	2012	Sierra	Body	Body Control Module																																								
1	2012	Sierra	Body	Body Control Module (aux.)																																								
1	2012	Sierra	Body	Digital Radio Receiver																																								
1	2012	Sierra	Body	Driver Door Switch																																								
1	2012	Sierra	Body	HVAC Control Module Auto																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2012	Sierra	Body	HVAC Control Module Manual																																								
1	2012	Sierra	Body	Instrument Panel Cluster																																								
1	2012	Sierra	Body	Memory Seat Module																																								
1	2012	Sierra	Body	Park Assist Module																																								
1	2012	Sierra	Body	Passenger Door Switch																																								
1	2012	Sierra	Body	Passenger Presence System																																								
1	2012	Sierra	Body	Radio																																								
1	2012	Sierra	Body	Navigation Radio																																								
1	2012	Sierra	Body	Rear Heated Seat Module																																								
1	2012	Sierra	Body	Rear HVAC/RSA																																								
1	2012	Sierra	Body	Supplemental Inflatable Restraint																																								
1	2012	Sierra	Body	Theft Deterrent Module																																								
1	2012	Sierra Hybrid	Powertrain	Engine Control Module																																								
1	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																								
1	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																								
1	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																								
1	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																								
1	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																								
1	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																								
1	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																								
1	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																								
1	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																								
1	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																								
1	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																								
1	2012	Sierra Hybrid	Body	Amplifier (Bose)																																								
1	2012	Sierra Hybrid	Body	Body Control Module																																								
1	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																								
1	2012	Sierra Hybrid	Body	Digital Radio Receiver																																								
1	2012	Sierra Hybrid	Body	Driver Door Switch																																								
1	2012	Sierra Hybrid	Body	Heated Seat Module																																								
1	2012	Sierra Hybrid	Body	HVAC Control Module																																								
1	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																								
1	2012	Sierra Hybrid	Body	Park Assist Module																																								
1	2012	Sierra Hybrid	Body	Passenger Door Switch																																								
1	2012	Sierra Hybrid	Body	Passenger Presence System																																								
1	2012	Sierra Hybrid	Body	Radio																																								
1	2012	Sierra Hybrid	Body	Navigation Radio																																								
1	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																								
1	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																								
1	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																								
1	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																								
1	2012	Sierra Hybrid	Body	Theft Deterrent Module																																								
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
1	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
1	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
1	2012	Yukon	Chassis	Electronic Brake Control Module																																								
1	2012	Yukon	Chassis	Electronic Suspension Control																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2012	Yukon	Chassis	Trailer Brake Control Module																																								
1	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																								
1	2012	Yukon	Body	Amplifier (Bose)																																								
1	2012	Yukon	Body	Assist Step Controller																																								
1	2012	Yukon	Body	Body Control Module																																								
1	2012	Yukon	Body	Body Control Module (aux.)																																								
1	2012	Yukon	Body	Digital Radio Receiver																																								
1	2012	Yukon	Body	Driver Door Switch																																								
1	2012	Yukon	Body	HVAC Control Module Auto																																								
1	2012	Yukon	Body	HVAC Control Module Manual																																								
1	2012	Yukon	Body	Instrument Panel Cluster																																								
1	2012	Yukon	Body	Left Side Object Detection Module																																								
1	2012	Yukon	Body	Lift Gate Module																																								
1	2012	Yukon	Body	Memory Seat Module																																								
1	2012	Yukon	Body	Park Assist Module																																								
1	2012	Yukon	Body	Passenger Door Switch																																								
1	2012	Yukon	Body	Passenger Presence System																																								
1	2012	Yukon	Body	Radio																																								
1	2012	Yukon	Body	Navigation Radio																																								
1	2012	Yukon	Body	Rear Heated Seat Module																																								
1	2012	Yukon	Body	Rear HVAC/RSA																																								
1	2012	Yukon	Body	Right Side Object Detection Module																																								
1	2012	Yukon	Body	Supplemental Inflatable Restraint																																								
1	2012	Yukon	Body	Theft Deterrent Module																																								
1	2012	Yukon Hybrid	Powertrain	Engine Control Module																																								
1	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																								
1	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																								
1	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																								
1	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																								
1	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																								
1	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																								
1	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																								
1	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																								
1	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																								
1	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																								
1	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																								
1	2012	Yukon Hybrid	Body	Amplifier (Bose)																																								
1	2012	Yukon Hybrid	Body	Assist Step Controller																																								
1	2012	Yukon Hybrid	Body	Body Control Module																																								
1	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																								
1	2012	Yukon Hybrid	Body	Digital Radio Receiver																																								
1	2012	Yukon Hybrid	Body	Driver Door Switch																																								
1	2012	Yukon Hybrid	Body	Heated Seat Module																																								
1	2012	Yukon Hybrid	Body	HVAC Control Module																																								
1	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																								
1	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																								
1	2012	Yukon Hybrid	Body	Lift Gate Module																																								
1	2012	Yukon Hybrid	Body	Park Assist Module																																								
1	2012	Yukon Hybrid	Body	Passenger Door Switch																																								
1	2012	Yukon Hybrid	Body	Passenger Presence System																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2012	Yukon Hybrid	Body	Radio																																								
1	2012	Yukon Hybrid	Body	Navigation Radio																																								
1	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																								
1	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																								
1	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																								
1	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																								
1	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																								
1	2012	Yukon Hybrid	Body	Theft Deterrent Module																																								
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
1	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
1	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
1	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
1	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
1	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																								
1	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																								
1	2012	Yukon XL	Chassis	Electronic Suspension Control																																								
1	2012	Yukon XL	Chassis	Trailer Brake Control Module																																								
1	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																								
1	2012	Yukon XL	Body	Amplifier (Bose)																																								
1	2012	Yukon XL	Body	Assist Step Controller																																								
1	2012	Yukon XL	Body	Body Control Module																																								
1	2012	Yukon XL	Body	Body Control Module (aux.)																																								
1	2012	Yukon XL	Body	Digital Radio Receiver																																								
1	2012	Yukon XL	Body	Driver Door Switch																																								
1	2012	Yukon XL	Body	HVAC Control Module Auto																																								
1	2012	Yukon XL	Body	HVAC Control Module Manual																																								
1	2012	Yukon XL	Body	Instrument Panel Cluster																																								
1	2012	Yukon XL	Body	Left Side Object Detection Module																																								
1	2012	Yukon XL	Body	Lift Gate Module																																								
1	2012	Yukon XL	Body	Memory Seat Module																																								
1	2012	Yukon XL	Body	Park Assist Module																																								
1	2012	Yukon XL	Body	Passenger Door Switch																																								
1	2012	Yukon XL	Body	Passenger Presence System																																								
1	2012	Yukon XL	Body	Radio																																								
1	2012	Yukon XL	Body	Navigation Radio																																								
1	2012	Yukon XL	Body	Rear Heated Seat Module																																								
1	2012	Yukon XL	Body	Rear HVAC/RSA																																								
1	2012	Yukon XL	Body	Right Side Object Detection Module																																								
1	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																								
1	2012	Yukon XL	Body	Theft Deterrent Module																																								
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
1	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
1	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
1	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
1	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
1	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																								
1	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
1	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																								
1	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								
1	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																								
1	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
1	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																								
1	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																								
1	2013	Sierra	Chassis	Electronic Suspension Control																																								
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																								
1	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																								
1	2013	Sierra	Body	Amplifier (Bose)																																								
1	2013	Sierra	Body	Body Control Module																																								
1	2013	Sierra	Body	Body Control Module (aux.)																																								
1	2013	Sierra	Body	Digital Radio Receiver																																								
1	2013	Sierra	Body	Driver Door Switch																																								
1	2013	Sierra	Body	HVAC Control Module Auto																																								
1	2013	Sierra	Body	HVAC Control Module Manual																																								
1	2013	Sierra	Body	Instrument Panel Cluster																																								
1	2013	Sierra	Body	Memory Seat Module																																								
1	2013	Sierra	Body	Park Assist Module																																								
1	2013	Sierra	Body	Passenger Door Switch																																								
1	2013	Sierra	Body	Passenger Presence System																																								
1	2013	Sierra	Body	Radio																																								
1	2013	Sierra	Body	Navigation Radio																																								
1	2013	Sierra	Body	Rear Heated Seat Module																																								
1	2013	Sierra	Body	Rear HVAC/RSA																																								
1	2013	Sierra	Body	Supplemental Inflatable Restraint																																								
1	2013	Sierra	Body	Theft Deterrent Module																																								
1	2013	Sierra Hybrid	Powertrain	Engine Control Module																																								
1	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																								
1	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																								
1	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																								
1	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																								
1	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																								
1	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																								
1	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																								
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																								
1	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																								
1	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																								
1	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																								
1	2013	Sierra Hybrid	Body	Amplifier (Bose)																																								
1	2013	Sierra Hybrid	Body	Body Control Module																																								
1	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																								
1	2013	Sierra Hybrid	Body	Digital Radio Receiver																																								
1	2013	Sierra Hybrid	Body	Driver Door Switch																																								
1	2013	Sierra Hybrid	Body	Heated Seat Module																																								
1	2013	Sierra Hybrid	Body	HVAC Control Module																																								
1	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																								
1	2013	Sierra Hybrid	Body	Park Assist Module																																								
1	2013	Sierra Hybrid	Body	Passenger Door Switch																																								
1	2013	Sierra Hybrid	Body	Passenger Presence System																																								
1	2013	Sierra Hybrid	Body	Radio																																								
1	2013	Sierra Hybrid	Body	Navigation Radio																																								
1	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																								
1	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																								
1	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																								
1	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																								
1	2013	Sierra Hybrid	Body	Theft Deterrent Module																																								
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
1	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
1	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
1	2013	Yukon	Chassis	Electronic Brake Control Module																																								
1	2013	Yukon	Chassis	Electronic Suspension Control																																								
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																								
1	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																								
1	2013	Yukon	Body	Amplifier (Bose)																																								
1	2013	Yukon	Body	Assist Step Controller																																								
1	2013	Yukon	Body	Body Control Module																																								
1	2013	Yukon	Body	Body Control Module (aux.)																																								
1	2013	Yukon	Body	Digital Radio Receiver																																								
1	2013	Yukon	Body	Driver Door Switch																																								
1	2013	Yukon	Body	HVAC Control Module Auto																																								
1	2013	Yukon	Body	HVAC Control Module Manual																																								
1	2013	Yukon	Body	Instrument Panel Cluster																																								
1	2013	Yukon	Body	Left Side Object Detection Module																																								
1	2013	Yukon	Body	Lift Gate Module																																								
1	2013	Yukon	Body	Memory Seat Module																																								
1	2013	Yukon	Body	Park Assist Module																																								
1	2013	Yukon	Body	Passenger Door Switch																																								
1	2013	Yukon	Body	Passenger Presence System																																								
1	2013	Yukon	Body	Radio																																								
1	2013	Yukon	Body	Navigation Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2013	Yukon	Body	Rear Heated Seat Module																																								
1	2013	Yukon	Body	Rear HVAC/RSA																																								
1	2013	Yukon	Body	Right Side Object Detection Module																																								
1	2013	Yukon	Body	Supplemental Inflatable Restraint																																								
1	2013	Yukon	Body	Theft Deterrent Module																																								
1	2013	Yukon Hybrid	Powertrain	Engine Control Module																																								
1	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																								
1	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																								
1	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																								
1	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																								
1	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																								
1	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																								
1	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																								
1	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																								
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																								
1	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																								
1	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																								
1	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																								
1	2013	Yukon Hybrid	Body	Amplifier (Bose)																																								
1	2013	Yukon Hybrid	Body	Assist Step Controller																																								
1	2013	Yukon Hybrid	Body	Body Control Module																																								
1	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																								
1	2013	Yukon Hybrid	Body	Digital Radio Receiver																																								
1	2013	Yukon Hybrid	Body	Driver Door Switch																																								
1	2013	Yukon Hybrid	Body	Heated Seat Module																																								
1	2013	Yukon Hybrid	Body	HVAC Control Module																																								
1	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																								
1	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																								
1	2013	Yukon Hybrid	Body	Lift Gate Module																																								
1	2013	Yukon Hybrid	Body	Park Assist Module																																								
1	2013	Yukon Hybrid	Body	Passenger Door Switch																																								
1	2013	Yukon Hybrid	Body	Passenger Presence System																																								
1	2013	Yukon Hybrid	Body	Radio																																								
1	2013	Yukon Hybrid	Body	Navigation Radio																																								
1	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																								
1	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																								
1	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																								
1	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																								
1	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																								
1	2013	Yukon Hybrid	Body	Theft Deterrent Module																																								
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
1	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
1	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
1	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
1	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																								
1	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																								
1	2013	Yukon XL	Chassis	Electronic Suspension Control																																								
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																								
1	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																								
1	2013	Yukon XL	Body	Amplifier (Bose)																																								
1	2013	Yukon XL	Body	Assist Step Controller																																								
1	2013	Yukon XL	Body	Body Control Module																																								
1	2013	Yukon XL	Body	Body Control Module (aux.)																																								
1	2013	Yukon XL	Body	Digital Radio Receiver																																								
1	2013	Yukon XL	Body	Driver Door Switch																																								
1	2013	Yukon XL	Body	HVAC Control Module Auto																																								
1	2013	Yukon XL	Body	HVAC Control Module Manual																																								
1	2013	Yukon XL	Body	Instrument Panel Cluster																																								
1	2013	Yukon XL	Body	Left Side Object Detection Module																																								
1	2013	Yukon XL	Body	Lift Gate Module																																								
1	2013	Yukon XL	Body	Memory Seat Module																																								
1	2013	Yukon XL	Body	Park Assist Module																																								
1	2013	Yukon XL	Body	Passenger Door Switch																																								
1	2013	Yukon XL	Body	Passenger Presence System																																								
1	2013	Yukon XL	Body	Radio																																								
1	2013	Yukon XL	Body	Navigation Radio																																								
1	2013	Yukon XL	Body	Rear Heated Seat Module																																								
1	2013	Yukon XL	Body	Rear HVAC/RSA																																								
1	2013	Yukon XL	Body	Right Side Object Detection Module																																								
1	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																								
1	2013	Yukon XL	Body	Theft Deterrent Module																																								
1	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
1	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
1	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																								
1	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
1	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																								
1	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
1	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
1	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																								
1	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
1	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
1	2014	Sierra	Chassis	Electronic Brake Control Module																																								
1	2014	Sierra	Chassis	Parking Brake Control Module																																								
1	2014	Sierra	Chassis	Power Steering Control Module																																								
1	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																								
1	2014	Sierra	Body	Body Control Module																																								
1	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
1	2014	Sierra	Body	Passenger Presence Module																																								
1	2014	Sierra	Body	Instrument Cluster																																								
1	2014	Sierra	Body	Radio Control																																								
1	2014	Sierra	Body	HVAC Control																																								
1	2014	Sierra	Body	Radio																																								
1	2014	Sierra	Body	Amplifier																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2014	Sierra	Body	Media Disc Player																																								
1	2014	Sierra	Body	Human Machine Interface Control Module																																								
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																								
1	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																								
1	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																								
1	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																								
1	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																								
1	2014	Sierra	Body	Parking Assist Control Module																																								
1	2014	Sierra	Body	Frontview Camera Module																																								
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																								
1	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																								
1	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																								
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																								
1	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
1	2014	Sierra HD	Powertrain	Transfer Case Control Module																																								
1	2014	Sierra HD	Chassis	Electronic Brake Control Module																																								
1	2014	Sierra HD	Chassis	Parking Brake Control Module																																								
1	2014	Sierra HD	Chassis	Trailer Brake Control Module																																								
1	2014	Sierra HD	Chassis	Suspension Control Module																																								
1	2014	Sierra HD	Body	Body Control Module																																								
1	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
1	2014	Sierra HD	Body	Instrument Cluster																																								
1	2014	Sierra HD	Body	Base Radio																																								
1	2014	Sierra HD	Body	Navigation Radio																																								
1	2014	Sierra HD	Body	Uplevel Radio																																								
1	2014	Sierra HD	Body	Amplifier																																								
1	2014	Sierra HD	Body	Rear Audio Control Module																																								
1	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																								
1	2014	Sierra HD	Body	Personal Audio Link Control Module																																								
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																								
1	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																								
1	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																								
1	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																								
1	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																								
1	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																								
1	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																								
1	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																								
1	2014	Sierra HD	Body	Seat Memory Control Module																																								
1	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																								
1	2014	Sierra HD	Body	Parking Assist Control Module																																								
1	2014	Sierra HD	Body	Theft Deterrent Module																																								
1	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																								
1	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																								
1	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																								
1	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																								
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																								
1	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																								
1	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
1	2014	Yukon	Chassis	Electronic Brake Control Module																																								
1	2014	Yukon	Chassis	Parking Brake Control Module																																								
1	2014	Yukon	Chassis	Suspension Control Module																																								
1	2014	Yukon	Body	Body Control Module																																								
1	2014	Yukon	Body	Auxiliary Body Control Module																																								
1	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
1	2014	Yukon	Body	Passenger Presence Module																																								
1	2014	Yukon	Body	Instrument Cluster																																								
1	2014	Yukon	Body	Base Radio																																								
1	2014	Yukon	Body	Navigation Radio																																								
1	2014	Yukon	Body	Uplevel Radio																																								
1	2014	Yukon	Body	Amplifier																																								
1	2014	Yukon	Body	Rear Audio Control Module																																								
1	2014	Yukon	Body	Digital Radio Receiver Control Module																																								
1	2014	Yukon	Body	Personal Audio Link Control Module																																								
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																								
1	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																								
1	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																								
1	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																								
1	2014	Yukon	Body	Driver Door Switch Panel Control Module																																								
1	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																								
1	2014	Yukon	Body	Liftgate Control Module																																								
1	2014	Yukon	Body	Seat Memory Control Module																																								
1	2014	Yukon	Body	Rear Seat Heating Control Module																																								
1	2014	Yukon	Body	Assist Step Control Module																																								
1	2014	Yukon	Body	Right Side Object Detection Control Module																																								
1	2014	Yukon	Body	Left Side Object Detection Control Module																																								
1	2014	Yukon	Body	Remote Control Door Lock Receiver																																								
1	2014	Yukon	Body	Parking Assist Control Module																																								
1	2014	Yukon	Body	Theft Deterrent Module																																								
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																								
1	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																								
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																								
1	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																								
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																								
1	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																								
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																								
1	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																								
1	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
1	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
1	2014	Yukon XL	Chassis	Electronic Brake Control Module																																								
1	2014	Yukon XL	Chassis	Parking Brake Control Module																																								
1	2014	Yukon XL	Chassis	Suspension Control Module																																								
1	2014	Yukon XL	Body	Body Control Module																																								
1	2014	Yukon XL	Body	Auxiliary Body Control Module																																								
1	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
1	2014	Yukon XL	Body	Passenger Presence Module																																								
1	2014	Yukon XL	Body	Instrument Cluster																																								
1	2014	Yukon XL	Body	Base Radio																																								
1	2014	Yukon XL	Body	Navigation Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2014	Yukon XL	Body	Uplevel Radio																																								
1	2014	Yukon XL	Body	Amplifier																																								
1	2014	Yukon XL	Body	Rear Audio Control Module																																								
1	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																								
1	2014	Yukon XL	Body	Personal Audio Link Control Module																																								
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																								
1	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																								
1	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																								
1	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																								
1	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																								
1	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																								
1	2014	Yukon XL	Body	Liftgate Control Module																																								
1	2014	Yukon XL	Body	Seat Memory Control Module																																								
1	2014	Yukon XL	Body	Rear Seat Heating Control Module																																								
1	2014	Yukon XL	Body	Assist Step Control Module																																								
1	2014	Yukon XL	Body	Right Side Object Detection Control Module																																								
1	2014	Yukon XL	Body	Left Side Object Detection Control Module																																								
1	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																								
1	2014	Yukon XL	Body	Parking Assist Control Module																																								
1	2014	Yukon XL	Body	Theft Deterrent Module																																								
1	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
1	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
1	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																								
1	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
1	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																								
1	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																								
1	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
1	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																								
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
1	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
1	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																								
1	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																								
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																								
1	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																								
1	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
1	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
1	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																								
1	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																								
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																								
1	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
1	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
1	2015	Sierra	Chassis	Electronic Brake Control Module																																								
1	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																								
1	2015	Sierra	Chassis	Power Steering Control Module																																								
1	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																								
1	2015	Sierra	Chassis	Suspension Control Module																																								
1	2015	Sierra	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
1	2015	Sierra	Body	Passenger Presence Module																																								
1	2015	Sierra	Body	Instrument Cluster																																								
1	2015	Sierra	Body	Radio Controls																																								
1	2015	Sierra	Body	HVAC Controls																																								
1	2015	Sierra	Body	Radio																																								
1	2015	Sierra	Body	Amplifier																																								
1	2015	Sierra	Body	Media Disc Player																																								
1	2015	Sierra	Body	Human Machine Interface Control Module																																								
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																								
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																								
1	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																								
1	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																								
1	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																								
1	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																								
1	2015	Sierra	Body	Parking Assist Control Module																																								
1	2015	Sierra	Body	Frontview Camera Module																																								
1	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																								
1	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
1	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																								
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
1	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
1	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																								
1	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																								
1	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																								
1	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
1	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
1	2015	Yukon	Powertrain	Drive Motor Control Module 1																																								
1	2015	Yukon	Powertrain	Drive Motor Control Module 2																																								
1	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																								
1	2015	Yukon	Chassis	Electronic Brake Control Module																																								
1	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																								
1	2015	Yukon	Chassis	Parking Brake Control Module																																								
1	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																								
1	2015	Yukon	Chassis	Power Steering Control Module																																								
1	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																								
1	2015	Yukon	Chassis	Suspension Control Module																																								
1	2015	Yukon	Body	Body Control Module																																								
1	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
1	2015	Yukon	Body	Passenger Presence Module																																								
1	2015	Yukon	Body	Instrument Cluster																																								
1	2015	Yukon	Body	Radio Controls																																								
1	2015	Yukon	Body	HVAC Controls																																								
1	2015	Yukon	Body	Radio																																								
1	2015	Yukon	Body	Amplifier																																								
1	2015	Yukon	Body	Media Disc Player																																								
1	2015	Yukon	Body	Human Machine Interface Control Module																																								
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																								
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																								
1	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2015	Yukon	Body	HVAC Control Module																																								
1	2015	Yukon	Body	Liftgate Control Module																																								
1	2015	Yukon	Body	Keyless Entry Control Module																																								
1	2015	Yukon	Body	Assist Step Control Module																																								
1	2015	Yukon	Body	Left Side Object Detection Control Module																																								
1	2015	Yukon	Body	Parking Assist Control Module																																								
1	2015	Yukon	Body	Frontview Camera Module																																								
1	2015	Yukon	Body	Steering Column Lock Control Module																																								
1	2015	Yukon	Body	Battery Energy Control Module																																								
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																								
1	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																								
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																								
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
1	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
1	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																								
1	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																								
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																								
1	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
1	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
1	2015	Yukon XL	Chassis	Electronic Brake Control Module																																								
1	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																								
1	2015	Yukon XL	Chassis	Parking Brake Control Module																																								
1	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																								
1	2015	Yukon XL	Chassis	Power Steering Control Module																																								
1	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																								
1	2015	Yukon XL	Chassis	Suspension Control Module																																								
1	2015	Yukon XL	Body	Body Control Module																																								
1	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
1	2015	Yukon XL	Body	Passenger Presence Module																																								
1	2015	Yukon XL	Body	Instrument Cluster																																								
1	2015	Yukon XL	Body	Radio Controls																																								
1	2015	Yukon XL	Body	HVAC Controls																																								
1	2015	Yukon XL	Body	Radio																																								
1	2015	Yukon XL	Body	Amplifier																																								
1	2015	Yukon XL	Body	Media Disc Player																																								
1	2015	Yukon XL	Body	Human Machine Interface Control Module																																								
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																								
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																								
1	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																								
1	2015	Yukon XL	Body	HVAC Control Module																																								
1	2015	Yukon XL	Body	Liftgate Control Module																																								
1	2015	Yukon XL	Body	Keyless Entry Control Module																																								
1	2015	Yukon XL	Body	Assist Step Control Module																																								
1	2015	Yukon XL	Body	Left Side Object Detection Control Module																																								
1	2015	Yukon XL	Body	Parking Assist Control Module																																								
1	2015	Yukon XL	Body	Frontview Camera Module																																								
1	2015	Yukon XL	Body	Steering Column Lock Control Module																																								
1	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
1	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																								
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																								
1	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																								
1	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																								
1	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																								
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																								
1	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																								
1	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																								
1	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																								
1	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
1	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																								
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
1	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
1	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																								
1	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																								
1	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																								
1	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																								
1	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
1	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
1	2016	Sierra	Chassis	Electronic Brake Control Module																																								
1	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																								
1	2016	Sierra	Chassis	Parking Brake Control Module																																								
1	2016	Sierra	Chassis	Power Steering Control Module																																								
1	2016	Sierra	Chassis	Power Steering Control Module																																								
1	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																								
1	2016	Sierra	Chassis	Suspension Control Module																																								
1	2016	Sierra	Body	Body Control Module																																								
1	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
1	2016	Sierra	Body	Passenger Presence Module																																								
1	2016	Sierra	Body	Instrument Cluster																																								
1	2016	Sierra	Body	Radio Controls																																								
1	2016	Sierra	Body	HVAC Controls																																								
1	2016	Sierra	Body	Radio (IO3)																																								
1	2016	Sierra	Body	Radio (IOB)																																								
1	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																								
1	2016	Sierra	Body	Amplifier																																								
1	2016	Sierra	Body	Media Disc Player																																								
1	2016	Sierra	Body	Human Machine Interface Control Module																																								
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																								
1	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																								
1	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																								
1	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																								
1	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																								
1	2016	Sierra	Body	Seat Memory Control Module - Driver																																								
1	2016	Sierra	Body	Assist Step Object Detection Control Module																																								
1	2016	Sierra	Body	Left Side Object Detection Control Module																																								
1	2016	Sierra	Body	Parking Assist Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2016	Sierra	Body	Frontview Camera Module																																								
1	2016	Sierra	Body	Frontview Camera Module																																								
1	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																								
1	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
1	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																								
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
1	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
1	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
1	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
1	2016	Yukon	Chassis	Electronic Brake Control Module																																								
1	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																								
1	2016	Yukon	Chassis	Parking Brake Control Module																																								
1	2016	Yukon	Chassis	Power Steering Control Module																																								
1	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																								
1	2016	Yukon	Chassis	Suspension Control Module																																								
1	2016	Yukon	Body	Body Control Module																																								
1	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
1	2016	Yukon	Body	Passenger Presence Module																																								
1	2016	Yukon	Body	Instrument Cluster																																								
1	2016	Yukon	Body	Radio Controls																																								
1	2016	Yukon	Body	HVAC Controls																																								
1	2016	Yukon	Body	Radio																																								
1	2016	Yukon	Body	Amplifier																																								
1	2016	Yukon	Body	Media Disc Player																																								
1	2016	Yukon	Body	Human Machine Interface Control Module																																								
1	2016	Yukon	Body	Telematics Communication Interface Control Module																																								
1	2016	Yukon	Body	HVAC Control Module																																								
1	2016	Yukon	Body	Liftgate Control Module																																								
1	2016	Yukon	Body	Seat Memory Control Module - Passenger																																								
1	2016	Yukon	Body	Seat Memory Control Module - Driver																																								
1	2016	Yukon	Body	Keyless Entry Control Module																																								
1	2016	Yukon	Body	Assist Step Control Module																																								
1	2016	Yukon	Body	Left Side Object Detection Control Module																																								
1	2016	Yukon	Body	Parking Assist Control Module																																								
1	2016	Yukon	Body	Frontview Camera Module																																								
1	2016	Yukon	Body	Steering Column Lock Control Module																																								
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																								
1	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																								
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
1	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
1	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
1	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
1	2016	Yukon XL	Chassis	Electronic Brake Control Module																																								
1	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																								
1	2016	Yukon XL	Chassis	Parking Brake Control Module																																								
1	2016	Yukon XL	Chassis	Power Steering Control Module																																								
1	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																								
1	2016	Yukon XL	Chassis	Suspension Control Module																																								
1	2016	Yukon XL	Body	Body Control Module																																								
1	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
1	2016	Yukon XL	Body	Passenger Presence Module																																								
1	2016	Yukon XL	Body	Instrument Cluster																																								
1	2016	Yukon XL	Body	Radio Controls																																								
1	2016	Yukon XL	Body	HVAC Controls																																								
1	2016	Yukon XL	Body	Radio																																								
1	2016	Yukon XL	Body	Amplifier																																								
1	2016	Yukon XL	Body	Media Disc Player																																								
1	2016	Yukon XL	Body	Human Machine Interface Control Module																																								
1	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																								
1	2016	Yukon XL	Body	HVAC Control Module																																								
1	2016	Yukon XL	Body	Liftgate Control Module																																								
1	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																								
1	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																								
1	2016	Yukon XL	Body	Keyless Entry Control Module																																								
1	2016	Yukon XL	Body	Assist Step Control Module																																								
1	2016	Yukon XL	Body	Left Side Object Detection Control Module																																								
1	2016	Yukon XL	Body	Parking Assist Control Module																																								
1	2016	Yukon XL	Body	Frontview Camera Module																																								
1	2016	Yukon XL	Body	Steering Column Lock Control Module																																								
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
2	2011	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
2	2011	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
2	2011	Sierra	Powertrain	(3)5.3L V8 LC9 Transfer Case Control Module																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
2	2011	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
2	2011	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
2	2011	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
2	2011	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								
2	2011	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2011	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																								
2	2011	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																								
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
2	2011	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
2	2011	Sierra	Chassis	Electronic Suspension Control																																								
2	2011	Sierra	Chassis	Trailer Brake Control Module																																								
2	2011	Sierra	Body	Amplifier (Bose)																																								
2	2011	Sierra	Body	Body Control Module																																								
2	2011	Sierra	Body	Body Control Module (aux.)																																								
2	2011	Sierra	Body	Digital Radio Receiver																																								
2	2011	Sierra	Body	Driver Door Switch																																								
2	2011	Sierra	Body	HVAC Control Module Auto																																								
2	2011	Sierra	Body	HVAC Control Module Manual																																								
2	2011	Sierra	Body	Instrument Panel Cluster																																								
2	2011	Sierra	Body	Memory Seat Module																																								
2	2011	Sierra	Body	Park Assist Module																																								
2	2011	Sierra	Body	Passenger Door Switch																																								
2	2011	Sierra	Body	Passenger Presence System																																								
2	2011	Sierra	Body	Radio																																								
2	2011	Sierra	Body	Rear Heated Seat Module																																								
2	2011	Sierra	Body	Rear HVAC/RSA																																								
2	2011	Sierra	Body	Supplemental Inflatable Restraint																																								
2	2011	Sierra	Body	Theft Deterrent Module																																								
2	2011	Sierra Hybrid	Powertrain	Engine Control Module																																								
2	2011	Sierra Hybrid	Powertrain	Accessory Power Module																																								
2	2011	Sierra Hybrid	Powertrain	Battery Energy Control Module																																								
2	2011	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																								
2	2011	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 1																																								
2	2011	Sierra Hybrid	Powertrain	Motor Control Modules 2																																								
2	2011	Sierra Hybrid	Powertrain	Transmission Control Module																																								
2	2011	Sierra Hybrid	Powertrain	Transfer Case Control Module																																								
2	2011	Sierra Hybrid	Chassis	Electronic Brake Control Module																																								
2	2011	Sierra Hybrid	Chassis	Electronic Suspension Control																																								
2	2011	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																								
2	2011	Sierra Hybrid	Chassis	Power Steering Control Module																																								
2	2011	Sierra Hybrid	Body	A/C Compressor Control Module																																								
2	2011	Sierra Hybrid	Body	Amplifier (Bose)																																								
2	2011	Sierra Hybrid	Body	Body Control Module																																								
2	2011	Sierra Hybrid	Body	Body Control Module (aux.)																																								
2	2011	Sierra Hybrid	Body	Digital Radio Receiver																																								
2	2011	Sierra Hybrid	Body	Driver Door Switch																																								
2	2011	Sierra Hybrid	Body	Heated Seat Module																																								
2	2011	Sierra Hybrid	Body	HVAC Control Module																																								
2	2011	Sierra Hybrid	Body	Instrument Panel Cluster																																								
2	2011	Sierra Hybrid	Body	Park Assist Module																																								
2	2011	Sierra Hybrid	Body	Passenger Door Switch																																								
2	2011	Sierra Hybrid	Body	Passenger Presence System																																								
2	2011	Sierra Hybrid	Body	Radio																																								
2	2011	Sierra Hybrid	Body	Rear Heated Seat Module																																								
2	2011	Sierra Hybrid	Body	Rear HVAC/RSA																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2011	Sierra Hybrid	Body	Serial Data Gateway Module																																								
2	2011	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																								
2	2011	Sierra Hybrid	Body	Theft Deterrent Module																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																								
2	2011	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																								
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
2	2011	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
2	2011	Yukon	Chassis	Electronic Brake Control Module																																								
2	2011	Yukon	Chassis	Electronic Suspension Control																																								
2	2011	Yukon	Chassis	Trailer Brake Control Module																																								
2	2011	Yukon	Chassis	FPCM with Trailer Brake Control																																								
2	2011	Yukon	Body	Amplifier (Bose)																																								
2	2011	Yukon	Body	Assist Step Controller																																								
2	2011	Yukon	Body	Body Control Module																																								
2	2011	Yukon	Body	Body Control Module (aux.)																																								
2	2011	Yukon	Body	Digital Radio Receiver																																								
2	2011	Yukon	Body	Driver Door Switch																																								
2	2011	Yukon	Body	HVAC Control Module Auto																																								
2	2011	Yukon	Body	HVAC Control Module Manual																																								
2	2011	Yukon	Body	Instrument Panel Cluster																																								
2	2011	Yukon	Body	Left Side Object Detection Module																																								
2	2011	Yukon	Body	Lift Gate Module																																								
2	2011	Yukon	Body	Memory Seat Module																																								
2	2011	Yukon	Body	Park Assist Module																																								
2	2011	Yukon	Body	Passenger Door Switch																																								
2	2011	Yukon	Body	Passenger Presence System																																								
2	2011	Yukon	Body	Radio																																								
2	2011	Yukon	Body	Rear Heated Seat Module																																								
2	2011	Yukon	Body	Rear HVAC/RSA																																								
2	2011	Yukon	Body	Right Side Object Detection Module																																								
2	2011	Yukon	Body	Supplemental Inflatable Restraint																																								
2	2011	Yukon	Body	Theft Deterrent Module																																								
2	2011	Yukon Hybrid	Powertrain	Engine Control Module																																								
2	2011	Yukon Hybrid	Powertrain	Accessory Power Module																																								
2	2011	Yukon Hybrid	Powertrain	Battery Energy Control Module																																								
2	2011	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																								
2	2011	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 1																																								
2	2011	Yukon Hybrid	Powertrain	Motor Control Modules 2																																								
2	2011	Yukon Hybrid	Powertrain	Transmission Control Module																																								
2	2011	Yukon Hybrid	Powertrain	Transfer Case Control Module																																								
2	2011	Yukon Hybrid	Chassis	Electronic Brake Control Module																																								
2	2011	Yukon Hybrid	Chassis	Electronic Suspension Control																																								
2	2011	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																								
2	2011	Yukon Hybrid	Chassis	Power Steering Control Module																																								
2	2011	Yukon Hybrid	Body	A/C Compressor Control Module																																								
2	2011	Yukon Hybrid	Body	Amplifier (Bose)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2011	Yukon Hybrid	Body	Assist Step Controller																																								
2	2011	Yukon Hybrid	Body	Body Control Module																																								
2	2011	Yukon Hybrid	Body	Body Control Module (aux.)																																								
2	2011	Yukon Hybrid	Body	Digital Radio Receiver																																								
2	2011	Yukon Hybrid	Body	Driver Door Switch																																								
2	2011	Yukon Hybrid	Body	Heated Seat Module																																								
2	2011	Yukon Hybrid	Body	HVAC Control Module																																								
2	2011	Yukon Hybrid	Body	Instrument Panel Cluster																																								
2	2011	Yukon Hybrid	Body	Left Side Object Detection Module																																								
2	2011	Yukon Hybrid	Body	Lift Gate Module																																								
2	2011	Yukon Hybrid	Body	Park Assist Module																																								
2	2011	Yukon Hybrid	Body	Passenger Door Switch																																								
2	2011	Yukon Hybrid	Body	Passenger Presence System																																								
2	2011	Yukon Hybrid	Body	Radio																																								
2	2011	Yukon Hybrid	Body	Rear Heated Seat Module																																								
2	2011	Yukon Hybrid	Body	Rear HVAC/RSA																																								
2	2011	Yukon Hybrid	Body	Right Side Object Detection Module																																								
2	2011	Yukon Hybrid	Body	Serial Data Gateway Module																																								
2	2011	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																								
2	2011	Yukon Hybrid	Body	Theft Deterrent Module																																								
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Engine Control Module																																								
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Fuel Pump Control Module																																								
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 Transmission Control Module																																								
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																								
2	2011	Yukon XL	Powertrain	(3)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																								
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																								
2	2011	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																								
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
2	2011	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
2	2011	Yukon XL	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
2	2011	Yukon XL	Chassis	EBCM Under 8600 GVW																																								
2	2011	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																								
2	2011	Yukon XL	Chassis	Electronic Suspension Control																																								
2	2011	Yukon XL	Chassis	Trailer Brake Control Module																																								
2	2011	Yukon XL	Chassis	FPCM with Trailer Brake Control																																								
2	2011	Yukon XL	Body	Amplifier (Bose)																																								
2	2011	Yukon XL	Body	Assist Step Controller																																								
2	2011	Yukon XL	Body	Body Control Module																																								
2	2011	Yukon XL	Body	Body Control Module (aux.)																																								
2	2011	Yukon XL	Body	Digital Radio Receiver																																								
2	2011	Yukon XL	Body	Driver Door Switch																																								
2	2011	Yukon XL	Body	HVAC Control Module Auto																																								
2	2011	Yukon XL	Body	HVAC Control Module Manual																																								
2	2011	Yukon XL	Body	Instrument Panel Cluster																																								
2	2011	Yukon XL	Body	Left Side Object Detection Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2011	Yukon XL	Body	Lift Gate Module																																								
2	2011	Yukon XL	Body	Memory Seat Module																																								
2	2011	Yukon XL	Body	Park Assist Module																																								
2	2011	Yukon XL	Body	Passenger Door Switch																																								
2	2011	Yukon XL	Body	Passenger Presence System																																								
2	2011	Yukon XL	Body	Radio																																								
2	2011	Yukon XL	Body	Rear Heated Seat Module																																								
2	2011	Yukon XL	Body	Rear HVAC/RSA																																								
2	2011	Yukon XL	Body	Right Side Object Detection Module																																								
2	2011	Yukon XL	Body	Supplemental Inflatable Restraint																																								
2	2011	Yukon XL	Body	Theft Deterrent Module																																								
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
2	2012	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
2	2012	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
2	2012	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
2	2012	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
2	2012	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
2	2012	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel PTO Control Module																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
2	2012	Sierra	Powertrain	(L)6.6L V8 LGH Diesel Transfer Case Control Module																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								
2	2012	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																								
2	2012	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																								
2	2012	Sierra	Chassis	EBCM Under 8600 GVW without VSES																																								
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
2	2012	Sierra	Chassis	EBCM Equal to or Over 8600 GVW Without VSES																																								
2	2012	Sierra	Chassis	Electronic Suspension Control																																								
2	2012	Sierra	Chassis	Trailer Brake Control Module																																								
2	2012	Sierra	Body	Amplifier (Bose)																																								
2	2012	Sierra	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2012	Sierra	Body	Body Control Module (aux.)																																								
2	2012	Sierra	Body	Digital Radio Receiver																																								
2	2012	Sierra	Body	Driver Door Switch																																								
2	2012	Sierra	Body	HVAC Control Module Auto																																								
2	2012	Sierra	Body	HVAC Control Module Manual																																								
2	2012	Sierra	Body	Instrument Panel Cluster																																								
2	2012	Sierra	Body	Memory Seat Module																																								
2	2012	Sierra	Body	Park Assist Module																																								
2	2012	Sierra	Body	Passenger Door Switch																																								
2	2012	Sierra	Body	Passenger Presence System																																								
2	2012	Sierra	Body	Radio																																								
2	2012	Sierra	Body	Navigation Radio																																								
2	2012	Sierra	Body	Rear Heated Seat Module																																								
2	2012	Sierra	Body	Rear HVAC/RSA																																								
2	2012	Sierra	Body	Supplemental Inflatable Restraint																																								
2	2012	Sierra	Body	Theft Deterrent Module																																								
2	2012	Sierra Hybrid	Powertrain	Engine Control Module																																								
2	2012	Sierra Hybrid	Powertrain	Accessory Power Module																																								
2	2012	Sierra Hybrid	Powertrain	Battery Energy Control Module																																								
2	2012	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																								
2	2012	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 1																																								
2	2012	Sierra Hybrid	Powertrain	Motor Control Modules 2																																								
2	2012	Sierra Hybrid	Powertrain	Transmission Control Module																																								
2	2012	Sierra Hybrid	Powertrain	Transfer Case Control Module																																								
2	2012	Sierra Hybrid	Chassis	Electronic Brake Control Module																																								
2	2012	Sierra Hybrid	Chassis	Electronic Suspension Control																																								
2	2012	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																								
2	2012	Sierra Hybrid	Chassis	Power Steering Control Module																																								
2	2012	Sierra Hybrid	Body	A/C Compressor Control Module																																								
2	2012	Sierra Hybrid	Body	Amplifier (Bose)																																								
2	2012	Sierra Hybrid	Body	Body Control Module																																								
2	2012	Sierra Hybrid	Body	Body Control Module (aux.)																																								
2	2012	Sierra Hybrid	Body	Digital Radio Receiver																																								
2	2012	Sierra Hybrid	Body	Driver Door Switch																																								
2	2012	Sierra Hybrid	Body	Heated Seat Module																																								
2	2012	Sierra Hybrid	Body	HVAC Control Module																																								
2	2012	Sierra Hybrid	Body	Instrument Panel Cluster																																								
2	2012	Sierra Hybrid	Body	Park Assist Module																																								
2	2012	Sierra Hybrid	Body	Passenger Door Switch																																								
2	2012	Sierra Hybrid	Body	Passenger Presence System																																								
2	2012	Sierra Hybrid	Body	Radio																																								
2	2012	Sierra Hybrid	Body	Navigation Radio																																								
2	2012	Sierra Hybrid	Body	Rear Heated Seat Module																																								
2	2012	Sierra Hybrid	Body	Rear HVAC/RSA																																								
2	2012	Sierra Hybrid	Body	Serial Data Gateway Module																																								
2	2012	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																								
2	2012	Sierra Hybrid	Body	Theft Deterrent Module																																								
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																								
2	2012	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																								
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
2	2012	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
2	2012	Yukon	Chassis	Electronic Brake Control Module																																								
2	2012	Yukon	Chassis	Electronic Suspension Control																																								
2	2012	Yukon	Chassis	Trailer Brake Control Module																																								
2	2012	Yukon	Chassis	FPCM with Trailer Brake Control																																								
2	2012	Yukon	Body	Amplifier (Bose)																																								
2	2012	Yukon	Body	Assist Step Controller																																								
2	2012	Yukon	Body	Body Control Module																																								
2	2012	Yukon	Body	Body Control Module (aux.)																																								
2	2012	Yukon	Body	Digital Radio Receiver																																								
2	2012	Yukon	Body	Driver Door Switch																																								
2	2012	Yukon	Body	HVAC Control Module Auto																																								
2	2012	Yukon	Body	HVAC Control Module Manual																																								
2	2012	Yukon	Body	Instrument Panel Cluster																																								
2	2012	Yukon	Body	Left Side Object Detection Module																																								
2	2012	Yukon	Body	Lift Gate Module																																								
2	2012	Yukon	Body	Memory Seat Module																																								
2	2012	Yukon	Body	Park Assist Module																																								
2	2012	Yukon	Body	Passenger Door Switch																																								
2	2012	Yukon	Body	Passenger Presence System																																								
2	2012	Yukon	Body	Radio																																								
2	2012	Yukon	Body	Navigation Radio																																								
2	2012	Yukon	Body	Rear Heated Seat Module																																								
2	2012	Yukon	Body	Rear HVAC/RSA																																								
2	2012	Yukon	Body	Right Side Object Detection Module																																								
2	2012	Yukon	Body	Supplemental Inflatable Restraint																																								
2	2012	Yukon	Body	Theft Deterrent Module																																								
2	2012	Yukon Hybrid	Powertrain	Engine Control Module																																								
2	2012	Yukon Hybrid	Powertrain	Accessory Power Module																																								
2	2012	Yukon Hybrid	Powertrain	Battery Energy Control Module																																								
2	2012	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																								
2	2012	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 1																																								
2	2012	Yukon Hybrid	Powertrain	Motor Control Modules 2																																								
2	2012	Yukon Hybrid	Powertrain	Transmission Control Module																																								
2	2012	Yukon Hybrid	Powertrain	Transfer Case Control Module																																								
2	2012	Yukon Hybrid	Chassis	Electronic Brake Control Module																																								
2	2012	Yukon Hybrid	Chassis	Electronic Suspension Control																																								
2	2012	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																								
2	2012	Yukon Hybrid	Chassis	Power Steering Control Module																																								
2	2012	Yukon Hybrid	Body	A/C Compressor Control Module																																								
2	2012	Yukon Hybrid	Body	Amplifier (Bose)																																								
2	2012	Yukon Hybrid	Body	Assist Step Controller																																								
2	2012	Yukon Hybrid	Body	Body Control Module																																								
2	2012	Yukon Hybrid	Body	Body Control Module (aux.)																																								
2	2012	Yukon Hybrid	Body	Digital Radio Receiver																																								
2	2012	Yukon Hybrid	Body	Driver Door Switch																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2012	Yukon Hybrid	Body	Heated Seat Module																																								
2	2012	Yukon Hybrid	Body	HVAC Control Module																																								
2	2012	Yukon Hybrid	Body	Instrument Panel Cluster																																								
2	2012	Yukon Hybrid	Body	Left Side Object Detection Module																																								
2	2012	Yukon Hybrid	Body	Lift Gate Module																																								
2	2012	Yukon Hybrid	Body	Park Assist Module																																								
2	2012	Yukon Hybrid	Body	Passenger Door Switch																																								
2	2012	Yukon Hybrid	Body	Passenger Presence System																																								
2	2012	Yukon Hybrid	Body	Radio																																								
2	2012	Yukon Hybrid	Body	Navigation Radio																																								
2	2012	Yukon Hybrid	Body	Rear Heated Seat Module																																								
2	2012	Yukon Hybrid	Body	Rear HVAC/RSA																																								
2	2012	Yukon Hybrid	Body	Right Side Object Detection Module																																								
2	2012	Yukon Hybrid	Body	Serial Data Gateway Module																																								
2	2012	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																								
2	2012	Yukon Hybrid	Body	Theft Deterrent Module																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																								
2	2012	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																								
2	2012	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																								
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
2	2012	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
2	2012	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
2	2012	Yukon XL	Chassis	EBCM Under 8600 GVW																																								
2	2012	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																								
2	2012	Yukon XL	Chassis	Electronic Suspension Control																																								
2	2012	Yukon XL	Chassis	Trailer Brake Control Module																																								
2	2012	Yukon XL	Chassis	FPCM with Trailer Brake Control																																								
2	2012	Yukon XL	Body	Amplifier (Bose)																																								
2	2012	Yukon XL	Body	Assist Step Controller																																								
2	2012	Yukon XL	Body	Body Control Module																																								
2	2012	Yukon XL	Body	Body Control Module (aux.)																																								
2	2012	Yukon XL	Body	Digital Radio Receiver																																								
2	2012	Yukon XL	Body	Driver Door Switch																																								
2	2012	Yukon XL	Body	HVAC Control Module Auto																																								
2	2012	Yukon XL	Body	HVAC Control Module Manual																																								
2	2012	Yukon XL	Body	Instrument Panel Cluster																																								
2	2012	Yukon XL	Body	Left Side Object Detection Module																																								
2	2012	Yukon XL	Body	Lift Gate Module																																								
2	2012	Yukon XL	Body	Memory Seat Module																																								
2	2012	Yukon XL	Body	Park Assist Module																																								
2	2012	Yukon XL	Body	Passenger Door Switch																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2012	Yukon XL	Body	Passenger Presence System																																								
2	2012	Yukon XL	Body	Radio																																								
2	2012	Yukon XL	Body	Navigation Radio																																								
2	2012	Yukon XL	Body	Rear Heated Seat Module																																								
2	2012	Yukon XL	Body	Rear HVAC/RSA																																								
2	2012	Yukon XL	Body	Right Side Object Detection Module																																								
2	2012	Yukon XL	Body	Supplemental Inflatable Restraint																																								
2	2012	Yukon XL	Body	Theft Deterrent Module																																								
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
2	2013	Sierra	Powertrain	(X)4.3L V6 LU3 Transfer Case Control Module																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Fuel Pump Control Module																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
2	2013	Sierra	Powertrain	(A)4.8L V8 L20 Transfer Case Control Module																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
2	2013	Sierra	Powertrain	(7)5.3L V8 LC9 Transfer Case Control Module																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
2	2013	Sierra	Powertrain	(0)5.3L V8 LMG Transfer Case Control Module																																								
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
2	2013	Sierra	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 CNG Control Module																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
2	2013	Sierra	Powertrain	(B)6.0L V8 LC8 Transfer Case Control Module																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Engine Control Module																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Fuel Pump Control Module																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transmission Control Module																																								
2	2013	Sierra	Powertrain	(2)6.2L V8 L9H Transfer Case Control Module																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Engine Control Module																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Glow Plug Control Module																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel PTO Control Module																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transmission Control Module																																								
2	2013	Sierra	Powertrain	(8)6.6L V8 LML Diesel Transfer Case Control Module																																								
2	2013	Sierra	Chassis	EBCM Under 8600 GVW with VSES																																								
2	2013	Sierra	Chassis	EBCM Equal to or Over 8600 GVW with VSES																																								
2	2013	Sierra	Chassis	Electronic Brake Control Module With VSES																																								
2	2013	Sierra	Chassis	Electronic Brake Control Module Without VSES																																								
2	2013	Sierra	Chassis	Electronic Suspension Control																																								
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																								
2	2013	Sierra	Chassis	FPCM with Trailer Brake Control																																								
2	2013	Sierra	Body	Amplifier (Bose)																																								
2	2013	Sierra	Body	Body Control Module																																								
2	2013	Sierra	Body	Body Control Module (aux.)																																								
2	2013	Sierra	Body	Digital Radio Receiver																																								
2	2013	Sierra	Body	Driver Door Switch																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2013	Sierra	Body	HVAC Control Module Auto																																								
2	2013	Sierra	Body	HVAC Control Module Manual																																								
2	2013	Sierra	Body	Instrument Panel Cluster																																								
2	2013	Sierra	Body	Memory Seat Module																																								
2	2013	Sierra	Body	Park Assist Module																																								
2	2013	Sierra	Body	Passenger Door Switch																																								
2	2013	Sierra	Body	Passenger Presence System																																								
2	2013	Sierra	Body	Radio																																								
2	2013	Sierra	Body	Navigation Radio																																								
2	2013	Sierra	Body	Rear Heated Seat Module																																								
2	2013	Sierra	Body	Rear HVAC/RSA																																								
2	2013	Sierra	Body	Supplemental Inflatable Restraint																																								
2	2013	Sierra	Body	Theft Deterrent Module																																								
2	2013	Sierra Hybrid	Powertrain	Engine Control Module																																								
2	2013	Sierra Hybrid	Powertrain	Accessory Power Module																																								
2	2013	Sierra Hybrid	Powertrain	Battery Energy Control Module																																								
2	2013	Sierra Hybrid	Powertrain	Fuel Pump Control Module																																								
2	2013	Sierra Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 1																																								
2	2013	Sierra Hybrid	Powertrain	Motor Control Modules 2																																								
2	2013	Sierra Hybrid	Powertrain	Transmission Control Module																																								
2	2013	Sierra Hybrid	Powertrain	Transfer Case Control Module																																								
2	2013	Sierra Hybrid	Chassis	Electronic Brake Control Module																																								
2	2013	Sierra Hybrid	Chassis	Electronic Suspension Control																																								
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																								
2	2013	Sierra Hybrid	Chassis	FPCM with Trailer Brake Control																																								
2	2013	Sierra Hybrid	Chassis	Power Steering Control Module																																								
2	2013	Sierra Hybrid	Body	A/C Compressor Control Module																																								
2	2013	Sierra Hybrid	Body	Amplifier (Bose)																																								
2	2013	Sierra Hybrid	Body	Body Control Module																																								
2	2013	Sierra Hybrid	Body	Body Control Module (aux.)																																								
2	2013	Sierra Hybrid	Body	Digital Radio Receiver																																								
2	2013	Sierra Hybrid	Body	Driver Door Switch																																								
2	2013	Sierra Hybrid	Body	Heated Seat Module																																								
2	2013	Sierra Hybrid	Body	HVAC Control Module																																								
2	2013	Sierra Hybrid	Body	Instrument Panel Cluster																																								
2	2013	Sierra Hybrid	Body	Park Assist Module																																								
2	2013	Sierra Hybrid	Body	Passenger Door Switch																																								
2	2013	Sierra Hybrid	Body	Passenger Presence System																																								
2	2013	Sierra Hybrid	Body	Radio																																								
2	2013	Sierra Hybrid	Body	Navigation Radio																																								
2	2013	Sierra Hybrid	Body	Rear Heated Seat Module																																								
2	2013	Sierra Hybrid	Body	Rear HVAC/RSA																																								
2	2013	Sierra Hybrid	Body	Serial Data Gateway Module																																								
2	2013	Sierra Hybrid	Body	Supplemental Inflatable Restraint																																								
2	2013	Sierra Hybrid	Body	Theft Deterrent Module																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																								
2	2013	Yukon	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
2	2013	Yukon	Powertrain	(F)6.2L V8 L94 Transmission Control Module																																								
2	2013	Yukon	Chassis	Electronic Brake Control Module																																								
2	2013	Yukon	Chassis	Electronic Suspension Control																																								
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																								
2	2013	Yukon	Chassis	FPCM with Trailer Brake Control																																								
2	2013	Yukon	Body	Amplifier (Bose)																																								
2	2013	Yukon	Body	Assist Step Controller																																								
2	2013	Yukon	Body	Body Control Module																																								
2	2013	Yukon	Body	Body Control Module (aux.)																																								
2	2013	Yukon	Body	Digital Radio Receiver																																								
2	2013	Yukon	Body	Driver Door Switch																																								
2	2013	Yukon	Body	HVAC Control Module Auto																																								
2	2013	Yukon	Body	HVAC Control Module Manual																																								
2	2013	Yukon	Body	Instrument Panel Cluster																																								
2	2013	Yukon	Body	Left Side Object Detection Module																																								
2	2013	Yukon	Body	Lift Gate Module																																								
2	2013	Yukon	Body	Memory Seat Module																																								
2	2013	Yukon	Body	Park Assist Module																																								
2	2013	Yukon	Body	Passenger Door Switch																																								
2	2013	Yukon	Body	Passenger Presence System																																								
2	2013	Yukon	Body	Radio																																								
2	2013	Yukon	Body	Navigation Radio																																								
2	2013	Yukon	Body	Rear Heated Seat Module																																								
2	2013	Yukon	Body	Rear HVAC/RSA																																								
2	2013	Yukon	Body	Right Side Object Detection Module																																								
2	2013	Yukon	Body	Supplemental Inflatable Restraint																																								
2	2013	Yukon	Body	Theft Deterrent Module																																								
2	2013	Yukon Hybrid	Powertrain	Engine Control Module																																								
2	2013	Yukon Hybrid	Powertrain	Accessory Power Module																																								
2	2013	Yukon Hybrid	Powertrain	Battery Energy Control Module																																								
2	2013	Yukon Hybrid	Powertrain	Fuel Pump Control Module																																								
2	2013	Yukon Hybrid	Powertrain	Hybrid Powertrain Control Module																																								
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 1																																								
2	2013	Yukon Hybrid	Powertrain	Motor Control Modules 2																																								
2	2013	Yukon Hybrid	Powertrain	Transmission Control Module																																								
2	2013	Yukon Hybrid	Powertrain	Transfer Case Control Module																																								
2	2013	Yukon Hybrid	Chassis	Electronic Brake Control Module																																								
2	2013	Yukon Hybrid	Chassis	Electronic Suspension Control																																								
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																								
2	2013	Yukon Hybrid	Chassis	FPCM with Trailer Brake Control																																								
2	2013	Yukon Hybrid	Chassis	Power Steering Control Module																																								
2	2013	Yukon Hybrid	Body	A/C Compressor Control Module																																								
2	2013	Yukon Hybrid	Body	Amplifier (Bose)																																								
2	2013	Yukon Hybrid	Body	Assist Step Controller																																								
2	2013	Yukon Hybrid	Body	Body Control Module																																								
2	2013	Yukon Hybrid	Body	Body Control Module (aux.)																																								
2	2013	Yukon Hybrid	Body	Digital Radio Receiver																																								
2	2013	Yukon Hybrid	Body	Driver Door Switch																																								
2	2013	Yukon Hybrid	Body	Heated Seat Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2013	Yukon Hybrid	Body	HVAC Control Module																																								
2	2013	Yukon Hybrid	Body	Instrument Panel Cluster																																								
2	2013	Yukon Hybrid	Body	Left Side Object Detection Module																																								
2	2013	Yukon Hybrid	Body	Lift Gate Module																																								
2	2013	Yukon Hybrid	Body	Park Assist Module																																								
2	2013	Yukon Hybrid	Body	Passenger Door Switch																																								
2	2013	Yukon Hybrid	Body	Passenger Presence System																																								
2	2013	Yukon Hybrid	Body	Radio																																								
2	2013	Yukon Hybrid	Body	Navigation Radio																																								
2	2013	Yukon Hybrid	Body	Rear Heated Seat Module																																								
2	2013	Yukon Hybrid	Body	Rear HVAC/RSA																																								
2	2013	Yukon Hybrid	Body	Right Side Object Detection Module																																								
2	2013	Yukon Hybrid	Body	Serial Data Gateway Module																																								
2	2013	Yukon Hybrid	Body	Supplemental Inflatable Restraint																																								
2	2013	Yukon Hybrid	Body	Theft Deterrent Module																																								
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Engine Control Module																																								
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Fuel Pump Control Module																																								
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 Transmission Control Module																																								
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 1 Speed ATC Transfer Case Control Module																																								
2	2013	Yukon XL	Powertrain	(7)5.3L V8 LC9 2 Speed ATC Transfer Case Control Module																																								
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Engine Control Module																																								
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Fuel Pump Control Module																																								
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG Transmission Control Module																																								
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 1 Speed ATC Transfer Case Control Module																																								
2	2013	Yukon XL	Powertrain	(0)5.3L V8 LMG 2 Speed ATC Transfer Case Control Module																																								
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
2	2013	Yukon XL	Powertrain	(G)6.0L V8 L96 Transfer Case Control Module																																								
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Fuel Pump Control Module																																								
2	2013	Yukon XL	Powertrain	(F)6.2L V8 L94 Engine Control Module																																								
2	2013	Yukon XL	Chassis	EBCM Under 8600 GVW																																								
2	2013	Yukon XL	Chassis	EBCM Equal to or Over 8600 GVW																																								
2	2013	Yukon XL	Chassis	Electronic Suspension Control																																								
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																								
2	2013	Yukon XL	Chassis	FPCM with Trailer Brake Control																																								
2	2013	Yukon XL	Body	Amplifier (Bose)																																								
2	2013	Yukon XL	Body	Assist Step Controller																																								
2	2013	Yukon XL	Body	Body Control Module																																								
2	2013	Yukon XL	Body	Body Control Module (aux.)																																								
2	2013	Yukon XL	Body	Digital Radio Receiver																																								
2	2013	Yukon XL	Body	Driver Door Switch																																								
2	2013	Yukon XL	Body	HVAC Control Module Auto																																								
2	2013	Yukon XL	Body	HVAC Control Module Manual																																								
2	2013	Yukon XL	Body	Instrument Panel Cluster																																								
2	2013	Yukon XL	Body	Left Side Object Detection Module																																								
2	2013	Yukon XL	Body	Lift Gate Module																																								
2	2013	Yukon XL	Body	Memory Seat Module																																								
2	2013	Yukon XL	Body	Park Assist Module																																								
2	2013	Yukon XL	Body	Passenger Door Switch																																								
2	2013	Yukon XL	Body	Passenger Presence System																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2013	Yukon XL	Body	Radio																																								
2	2013	Yukon XL	Body	Navigation Radio																																								
2	2013	Yukon XL	Body	Rear Heated Seat Module																																								
2	2013	Yukon XL	Body	Rear HVAC/RSA																																								
2	2013	Yukon XL	Body	Right Side Object Detection Module																																								
2	2013	Yukon XL	Body	Supplemental Inflatable Restraint																																								
2	2013	Yukon XL	Body	Theft Deterrent Module																																								
2	2014	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
2	2014	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
2	2014	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																								
2	2014	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
2	2014	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																								
2	2014	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module																																								
2	2014	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
2	2014	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																								
2	2014	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
2	2014	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
2	2014	Sierra	Chassis	Electronic Brake Control Module																																								
2	2014	Sierra	Chassis	Parking Brake Control Module																																								
2	2014	Sierra	Chassis	Power Steering Control Module																																								
2	2014	Sierra	Chassis	Steering Wheel Angle Sensor Module																																								
2	2014	Sierra	Body	Body Control Module																																								
2	2014	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
2	2014	Sierra	Body	Passenger Presence Module																																								
2	2014	Sierra	Body	Instrument Cluster																																								
2	2014	Sierra	Body	Radio Control																																								
2	2014	Sierra	Body	HVAC Control																																								
2	2014	Sierra	Body	Radio																																								
2	2014	Sierra	Body	Amplifier																																								
2	2014	Sierra	Body	Media Disc Player																																								
2	2014	Sierra	Body	Human Machine Interface Control Module																																								
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 9																																								
2	2014	Sierra	Body	Telematics Communication Interface Control Module Version 10																																								
2	2014	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																								
2	2014	Sierra	Body	HVAC Manual Control Heater Only (C42)																																								
2	2014	Sierra	Body	HVAC Manual Control Single Zone (C67)																																								
2	2014	Sierra	Body	Parking Assist Control Module																																								
2	2014	Sierra	Body	Frontview Camera Module																																								
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Engine Control Module																																								
2	2014	Sierra HD	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																								
2	2014	Sierra HD	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Engine Control Module																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Glow Plug Control Module																																								
2	2014	Sierra HD	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
2	2014	Sierra HD	Powertrain	Transfer Case Control Module																																								
2	2014	Sierra HD	Chassis	Electronic Brake Control Module																																								
2	2014	Sierra HD	Chassis	Parking Brake Control Module																																								
2	2014	Sierra HD	Chassis	Trailer Brake Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2014	Sierra HD	Chassis	Suspension Control Module																																								
2	2014	Sierra HD	Body	Body Control Module																																								
2	2014	Sierra HD	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
2	2014	Sierra HD	Body	Instrument Cluster																																								
2	2014	Sierra HD	Body	Base Radio																																								
2	2014	Sierra HD	Body	Navigation Radio																																								
2	2014	Sierra HD	Body	Uplevel Radio																																								
2	2014	Sierra HD	Body	Amplifier																																								
2	2014	Sierra HD	Body	Rear Audio Control Module																																								
2	2014	Sierra HD	Body	Digital Radio Receiver Control Module																																								
2	2014	Sierra HD	Body	Personal Audio Link Control Module																																								
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 9																																								
2	2014	Sierra HD	Body	Telematics Communication Interface Control Module Version 10																																								
2	2014	Sierra HD	Body	HVAC Auto Control Dual Zone (CJ2)																																								
2	2014	Sierra HD	Body	HVAC Manual Control Heater Only (C42)																																								
2	2014	Sierra HD	Body	HVAC Manual Control Dual Zone (CJ3)																																								
2	2014	Sierra HD	Body	HVAC Manual Control Single Zone (C67)																																								
2	2014	Sierra HD	Body	Driver Door Switch Panel Control Module																																								
2	2014	Sierra HD	Body	Passenger Door Switch Panel Control Module																																								
2	2014	Sierra HD	Body	Seat Memory Control Module																																								
2	2014	Sierra HD	Body	Remote Control Door Lock Receiver																																								
2	2014	Sierra HD	Body	Parking Assist Control Module																																								
2	2014	Sierra HD	Body	Theft Deterrent Module																																								
2	2014	Yukon	Powertrain	(0) 5.3L LMG Engine Control Module																																								
2	2014	Yukon	Powertrain	(0) 5.3L LMG Transmission Control Module																																								
2	2014	Yukon	Powertrain	(F) 6.2L L94 Engine Control Module																																								
2	2014	Yukon	Powertrain	(F) 6.2L L94 Transmission Control Module																																								
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump																																								
2	2014	Yukon	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																								
2	2014	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
2	2014	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
2	2014	Yukon	Chassis	Electronic Brake Control Module																																								
2	2014	Yukon	Chassis	Parking Brake Control Module																																								
2	2014	Yukon	Chassis	Suspension Control Module																																								
2	2014	Yukon	Body	Body Control Module																																								
2	2014	Yukon	Body	Auxiliary Body Control Module																																								
2	2014	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
2	2014	Yukon	Body	Passenger Presence Module																																								
2	2014	Yukon	Body	Instrument Cluster																																								
2	2014	Yukon	Body	Base Radio																																								
2	2014	Yukon	Body	Navigation Radio																																								
2	2014	Yukon	Body	Uplevel Radio																																								
2	2014	Yukon	Body	Amplifier																																								
2	2014	Yukon	Body	Rear Audio Control Module																																								
2	2014	Yukon	Body	Digital Radio Receiver Control Module																																								
2	2014	Yukon	Body	Personal Audio Link Control Module																																								
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 9																																								
2	2014	Yukon	Body	Telematics Communication Interface Control Module Version 10																																								
2	2014	Yukon	Body	HVAC Auto Control Dual Zone (CJ2)																																								
2	2014	Yukon	Body	HVAC Manual Control Dual Zone (CJ3)																																								
2	2014	Yukon	Body	Driver Door Switch Panel Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2014	Yukon	Body	Passenger Door Switch Panel Control Module																																								
2	2014	Yukon	Body	Liftgate Control Module																																								
2	2014	Yukon	Body	Seat Memory Control Module																																								
2	2014	Yukon	Body	Rear Seat Heating Control Module																																								
2	2014	Yukon	Body	Assist Step Control Module																																								
2	2014	Yukon	Body	Right Side Object Detection Control Module																																								
2	2014	Yukon	Body	Left Side Object Detection Control Module																																								
2	2014	Yukon	Body	Remote Control Door Lock Receiver																																								
2	2014	Yukon	Body	Parking Assist Control Module																																								
2	2014	Yukon	Body	Theft Deterrent Module																																								
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Engine Control Module																																								
2	2014	Yukon XL	Powertrain	(7) 5.3L LC9 Transmission Control Module																																								
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Engine Control Module																																								
2	2014	Yukon XL	Powertrain	(0) 5.3L LMG Transmission Control Module																																								
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Engine Control Module																																								
2	2014	Yukon XL	Powertrain	(F) 6.2L L94 Transmission Control Module																																								
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump																																								
2	2014	Yukon XL	Powertrain	Chassis Control Version Fuel Pump and Trailer Brake Control																																								
2	2014	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
2	2014	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
2	2014	Yukon XL	Chassis	Electronic Brake Control Module																																								
2	2014	Yukon XL	Chassis	Parking Brake Control Module																																								
2	2014	Yukon XL	Chassis	Suspension Control Module																																								
2	2014	Yukon XL	Body	Body Control Module																																								
2	2014	Yukon XL	Body	Auxiliary Body Control Module																																								
2	2014	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
2	2014	Yukon XL	Body	Passenger Presence Module																																								
2	2014	Yukon XL	Body	Instrument Cluster																																								
2	2014	Yukon XL	Body	Base Radio																																								
2	2014	Yukon XL	Body	Navigation Radio																																								
2	2014	Yukon XL	Body	Uplevel Radio																																								
2	2014	Yukon XL	Body	Amplifier																																								
2	2014	Yukon XL	Body	Rear Audio Control Module																																								
2	2014	Yukon XL	Body	Digital Radio Receiver Control Module																																								
2	2014	Yukon XL	Body	Personal Audio Link Control Module																																								
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 9																																								
2	2014	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																								
2	2014	Yukon XL	Body	HVAC Auto Control Dual Zone (CJ2)																																								
2	2014	Yukon XL	Body	HVAC Manual Control Dual Zone (CJ3)																																								
2	2014	Yukon XL	Body	Driver Door Switch Panel Control Module																																								
2	2014	Yukon XL	Body	Passenger Door Switch Panel Control Module																																								
2	2014	Yukon XL	Body	Liftgate Control Module																																								
2	2014	Yukon XL	Body	Seat Memory Control Module																																								
2	2014	Yukon XL	Body	Rear Seat Heating Control Module																																								
2	2014	Yukon XL	Body	Assist Step Control Module																																								
2	2014	Yukon XL	Body	Right Side Object Detection Control Module																																								
2	2014	Yukon XL	Body	Left Side Object Detection Control Module																																								
2	2014	Yukon XL	Body	Remote Control Door Lock Receiver																																								
2	2014	Yukon XL	Body	Parking Assist Control Module																																								
2	2014	Yukon XL	Body	Theft Deterrent Module																																								
2	2015	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
2	2015	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
2	2015	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																								
2	2015	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
2	2015	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																								
2	2015	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																								
2	2015	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
2	2015	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																								
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
2	2015	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
2	2015	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																								
2	2015	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																								
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015.5 (AVF)																																								
2	2015	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module My 2015 (WMF)																																								
2	2015	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
2	2015	Sierra	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
2	2015	Sierra	Powertrain	Chassis Control Version Trailer Brake Control																																								
2	2015	Sierra	Powertrain	Transfer Case Version Two Wheel Drive																																								
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																								
2	2015	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
2	2015	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
2	2015	Sierra	Chassis	Electronic Brake Control Module																																								
2	2015	Sierra	Chassis	Distance Sensing Cruise Control Module																																								
2	2015	Sierra	Chassis	Power Steering Control Module																																								
2	2015	Sierra	Chassis	Steering Wheel Angle Sensor Module																																								
2	2015	Sierra	Chassis	Suspension Control Module																																								
2	2015	Sierra	Body	Body Control Module																																								
2	2015	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
2	2015	Sierra	Body	Passenger Presence Module																																								
2	2015	Sierra	Body	Instrument Cluster																																								
2	2015	Sierra	Body	Radio Controls																																								
2	2015	Sierra	Body	HVAC Controls																																								
2	2015	Sierra	Body	Radio																																								
2	2015	Sierra	Body	Amplifier																																								
2	2015	Sierra	Body	Media Disc Player																																								
2	2015	Sierra	Body	Human Machine Interface Control Module																																								
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.6																																								
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																								
2	2015	Sierra	Body	Telematics Communication Interface Control Module Version 10																																								
2	2015	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																								
2	2015	Sierra	Body	HVAC Manual Control Heater Only (C42)																																								
2	2015	Sierra	Body	HVAC Manual Control Single Zone (C67)																																								
2	2015	Sierra	Body	Parking Assist Control Module																																								
2	2015	Sierra	Body	Frontview Camera Module																																								
2	2015	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																								
2	2015	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
2	2015	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																								
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2015	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
2	2015	Yukon	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control																																								
2	2015	Yukon	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																								
2	2015	Yukon	Powertrain	Transfer Case Version Two Wheel Drive																																								
2	2015	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
2	2015	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
2	2015	Yukon	Powertrain	Drive Motor Control Module 1																																								
2	2015	Yukon	Powertrain	Drive Motor Control Module 2																																								
2	2015	Yukon	Powertrain	Auxiliary Transmission Fluid Pump																																								
2	2015	Yukon	Chassis	Electronic Brake Control Module																																								
2	2015	Yukon	Chassis	Distance Sensing Cruise Control Module																																								
2	2015	Yukon	Chassis	Parking Brake Control Module																																								
2	2015	Yukon	Chassis	Multi-Axis Acceleration Sensor Module																																								
2	2015	Yukon	Chassis	Power Steering Control Module																																								
2	2015	Yukon	Chassis	Steering Wheel Angle Sensor Module																																								
2	2015	Yukon	Chassis	Suspension Control Module																																								
2	2015	Yukon	Body	Body Control Module																																								
2	2015	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
2	2015	Yukon	Body	Passenger Presence Module																																								
2	2015	Yukon	Body	Instrument Cluster																																								
2	2015	Yukon	Body	Radio Controls																																								
2	2015	Yukon	Body	HVAC Controls																																								
2	2015	Yukon	Body	Radio																																								
2	2015	Yukon	Body	Amplifier																																								
2	2015	Yukon	Body	Media Disc Player																																								
2	2015	Yukon	Body	Human Machine Interface Control Module																																								
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.6																																								
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 9.7																																								
2	2015	Yukon	Body	Telematics Communication Interface Control Module Version 10																																								
2	2015	Yukon	Body	HVAC Control Module																																								
2	2015	Yukon	Body	Liftgate Control Module																																								
2	2015	Yukon	Body	Keyless Entry Control Module																																								
2	2015	Yukon	Body	Assist Step Control Module																																								
2	2015	Yukon	Body	Left Side Object Detection Control Module																																								
2	2015	Yukon	Body	Parking Assist Control Module																																								
2	2015	Yukon	Body	Frontview Camera Module																																								
2	2015	Yukon	Body	Steering Column Lock Control Module																																								
2	2015	Yukon	Body	Battery Energy Control Module																																								
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																								
2	2015	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																								
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																								
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
2	2015	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
2	2015	Yukon XL	Powertrain	Chassis Control Version Active Grille Air Shutter																																								
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control																																								
2	2015	Yukon XL	Powertrain	Chassis Control Version Trailer Brake Control and Automatic Level Control																																								
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Wheel Drive																																								
2	2015	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
2	2015	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
2	2015	Yukon XL	Chassis	Electronic Brake Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2015	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																								
2	2015	Yukon XL	Chassis	Parking Brake Control Module																																								
2	2015	Yukon XL	Chassis	Multi-Axis Acceleration Sensor Module																																								
2	2015	Yukon XL	Chassis	Power Steering Control Module																																								
2	2015	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																								
2	2015	Yukon XL	Chassis	Suspension Control Module																																								
2	2015	Yukon XL	Body	Body Control Module																																								
2	2015	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
2	2015	Yukon XL	Body	Passenger Presence Module																																								
2	2015	Yukon XL	Body	Instrument Cluster																																								
2	2015	Yukon XL	Body	Radio Controls																																								
2	2015	Yukon XL	Body	HVAC Controls																																								
2	2015	Yukon XL	Body	Radio																																								
2	2015	Yukon XL	Body	Amplifier																																								
2	2015	Yukon XL	Body	Media Disc Player																																								
2	2015	Yukon XL	Body	Human Machine Interface Control Module																																								
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.6																																								
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 9.7																																								
2	2015	Yukon XL	Body	Telematics Communication Interface Control Module Version 10																																								
2	2015	Yukon XL	Body	HVAC Control Module																																								
2	2015	Yukon XL	Body	Liftgate Control Module																																								
2	2015	Yukon XL	Body	Keyless Entry Control Module																																								
2	2015	Yukon XL	Body	Assist Step Control Module																																								
2	2015	Yukon XL	Body	Left Side Object Detection Control Module																																								
2	2015	Yukon XL	Body	Parking Assist Control Module																																								
2	2015	Yukon XL	Body	Frontview Camera Module																																								
2	2015	Yukon XL	Body	Steering Column Lock Control Module																																								
2	2016	Sierra	Powertrain	(P) 4.3L LV1 Engine Control Module																																								
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Engine Control Module																																								
2	2016	Sierra	Powertrain	(H) 4.3L LV3 Transmission Control Module																																								
2	2016	Sierra	Powertrain	(C) 5.3L L83 Engine Control Module																																								
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 6 Speed																																								
2	2016	Sierra	Powertrain	(C) 5.3L L83 Transmission Control Module 8 Speed																																								
2	2016	Sierra	Powertrain	(R) 5.3L L8B Engine Control Module																																								
2	2016	Sierra	Powertrain	(R) 5.3L L8B Transmission Control Module																																								
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module																																								
2	2016	Sierra	Powertrain	(R) 5.3L L8B Hybrid Powertrain Control Module 2																																								
2	2016	Sierra	Powertrain	(G) 6.0L L96 Engine Control Module																																								
2	2016	Sierra	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Fuel Injector Control Module																																								
2	2016	Sierra	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
2	2016	Sierra	Powertrain	(J) 6.2L L86 Engine Control Module																																								
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
2	2016	Sierra	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
2	2016	Sierra	Powertrain	(8) 6.6L LML Engine Control Module																																								
2	2016	Sierra	Powertrain	(8) 6.6L LML Glow Plug Control Module																																								
2	2016	Sierra	Powertrain	(8) 6.6L LML Transmission Control Module																																								
2	2016	Sierra	Powertrain	(8) 6.6L LML Power Take-Off Control Module																																								
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Electric Shift (NQF)																																								
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Manual Shift (NQG)																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2016	Sierra	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
2	2016	Sierra	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
2	2016	Sierra	Chassis	Electronic Brake Control Module																																								
2	2016	Sierra	Chassis	Distance Sensing Cruise Control Module																																								
2	2016	Sierra	Chassis	Parking Brake Control Module																																								
2	2016	Sierra	Chassis	Power Steering Control Module																																								
2	2016	Sierra	Chassis	Power Steering Control Module																																								
2	2016	Sierra	Chassis	Steering Wheel Angle Sensor Module																																								
2	2016	Sierra	Chassis	Suspension Control Module																																								
2	2016	Sierra	Body	Body Control Module																																								
2	2016	Sierra	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
2	2016	Sierra	Body	Passenger Presence Module																																								
2	2016	Sierra	Body	Instrument Cluster																																								
2	2016	Sierra	Body	Radio Controls																																								
2	2016	Sierra	Body	HVAC Controls																																								
2	2016	Sierra	Body	Radio (IO3)																																								
2	2016	Sierra	Body	Radio (IOB)																																								
2	2016	Sierra	Body	Uplevel Radio (IO4 IO5 IO6)																																								
2	2016	Sierra	Body	Amplifier																																								
2	2016	Sierra	Body	Media Disc Player																																								
2	2016	Sierra	Body	Human Machine Interface Control Module																																								
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 9.7																																								
2	2016	Sierra	Body	Telematics Communication Interface Control Module Version 10																																								
2	2016	Sierra	Body	HVAC Auto Control Dual Zone (CJ2)																																								
2	2016	Sierra	Body	HVAC Manual Control Heater Only (C42)																																								
2	2016	Sierra	Body	HVAC Manual Control Single Zone (C67)																																								
2	2016	Sierra	Body	Seat Memory Control Module - Driver																																								
2	2016	Sierra	Body	Assist Step Object Detection Control Module																																								
2	2016	Sierra	Body	Left Side Object Detection Control Module																																								
2	2016	Sierra	Body	Parking Assist Control Module																																								
2	2016	Sierra	Body	Frontview Camera Module																																								
2	2016	Sierra	Body	Frontview Camera Module																																								
2	2016	Yukon	Powertrain	(C) 5.3L L83 Engine Control Module																																								
2	2016	Yukon	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
2	2016	Yukon	Powertrain	(J) 6.2L L86 Engine Control Module																																								
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
2	2016	Yukon	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
2	2016	Yukon	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
2	2016	Yukon	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
2	2016	Yukon	Chassis	Electronic Brake Control Module																																								
2	2016	Yukon	Chassis	Distance Sensing Cruise Control Module																																								
2	2016	Yukon	Chassis	Parking Brake Control Module																																								
2	2016	Yukon	Chassis	Power Steering Control Module																																								
2	2016	Yukon	Chassis	Steering Wheel Angle Sensor Module																																								
2	2016	Yukon	Chassis	Suspension Control Module																																								
2	2016	Yukon	Body	Body Control Module																																								
2	2016	Yukon	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
2	2016	Yukon	Body	Passenger Presence Module																																								
2	2016	Yukon	Body	Instrument Cluster																																								
2	2016	Yukon	Body	Radio Controls																																								
2	2016	Yukon	Body	HVAC Controls																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
2	2016	Yukon	Body	Radio																																								
2	2016	Yukon	Body	Amplifier																																								
2	2016	Yukon	Body	Media Disc Player																																								
2	2016	Yukon	Body	Human Machine Interface Control Module																																								
2	2016	Yukon	Body	Telematics Communication Interface Control Module																																								
2	2016	Yukon	Body	HVAC Control Module																																								
2	2016	Yukon	Body	Liftgate Control Module																																								
2	2016	Yukon	Body	Seat Memory Control Module - Passenger																																								
2	2016	Yukon	Body	Seat Memory Control Module - Driver																																								
2	2016	Yukon	Body	Keyless Entry Control Module																																								
2	2016	Yukon	Body	Assist Step Control Module																																								
2	2016	Yukon	Body	Left Side Object Detection Control Module																																								
2	2016	Yukon	Body	Parking Assist Control Module																																								
2	2016	Yukon	Body	Frontview Camera Module																																								
2	2016	Yukon	Body	Steering Column Lock Control Module																																								
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Engine Control Module																																								
2	2016	Yukon XL	Powertrain	(C) 5.3L L83 Transmission Control Module																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Engine Control Module																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 6 Speed																																								
2	2016	Yukon XL	Powertrain	(J) 6.2L L86 Transmission Control Module 8 Speed																																								
2	2016	Yukon XL	Powertrain	Transfer Case Version Two Speed Switch Activated (NQH)																																								
2	2016	Yukon XL	Powertrain	Transfer Case Version Single Speed Switch Activated (NP0)																																								
2	2016	Yukon XL	Chassis	Electronic Brake Control Module																																								
2	2016	Yukon XL	Chassis	Distance Sensing Cruise Control Module																																								
2	2016	Yukon XL	Chassis	Parking Brake Control Module																																								
2	2016	Yukon XL	Chassis	Power Steering Control Module																																								
2	2016	Yukon XL	Chassis	Steering Wheel Angle Sensor Module																																								
2	2016	Yukon XL	Chassis	Suspension Control Module																																								
2	2016	Yukon XL	Body	Body Control Module																																								
2	2016	Yukon XL	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
2	2016	Yukon XL	Body	Passenger Presence Module																																								
2	2016	Yukon XL	Body	Instrument Cluster																																								
2	2016	Yukon XL	Body	Radio Controls																																								
2	2016	Yukon XL	Body	HVAC Controls																																								
2	2016	Yukon XL	Body	Radio																																								
2	2016	Yukon XL	Body	Amplifier																																								
2	2016	Yukon XL	Body	Media Disc Player																																								
2	2016	Yukon XL	Body	Human Machine Interface Control Module																																								
2	2016	Yukon XL	Body	Telematics Communication Interface Control Module																																								
2	2016	Yukon XL	Body	HVAC Control Module																																								
2	2016	Yukon XL	Body	Liftgate Control Module																																								
2	2016	Yukon XL	Body	Seat Memory Control Module - Passenger																																								
2	2016	Yukon XL	Body	Seat Memory Control Module - Driver																																								
2	2016	Yukon XL	Body	Keyless Entry Control Module																																								
2	2016	Yukon XL	Body	Assist Step Control Module																																								
2	2016	Yukon XL	Body	Left Side Object Detection Control Module																																								
2	2016	Yukon XL	Body	Parking Assist Control Module																																								
2	2016	Yukon XL	Body	Frontview Camera Module																																								
2	2016	Yukon XL	Body	Steering Column Lock Control Module																																								
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
5	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
5	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																								
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																								
5	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																								
5	2011	ALL	Chassis	Electronic Brake Control Module																																								
5	2011	ALL	Body	Body Control Module																																								
5	2011	ALL	Body	Digital Radio Receiver																																								
5	2011	ALL	Body	Generator Battery Control Module																																								
5	2011	ALL	Body	Instrument Panel Cluster																																								
5	2011	ALL	Body	Passenger Presence System																																								
5	2011	ALL	Body	Personal Audio Link Module																																								
5	2011	ALL	Body	Base Radio																																								
5	2011	ALL	Body	Uplevel Radio																																								
5	2011	ALL	Body	Supplemental Inflatable Restraint																																								
5	2011	ALL	Body	Theft Deterrent Module																																								
5	2011	ALL	Body	Vehicle Comm. Interface Module								V																																
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
5	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
5	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																								
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																								
5	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																								
5	2012	ALL	Chassis	Electronic Brake Control Module																																								
5	2012	ALL	Body	Body Control Module																																								
5	2012	ALL	Body	Digital Radio Receiver																																								
5	2012	ALL	Body	Generator Battery Control Module																																								
5	2012	ALL	Body	Instrument Panel Cluster																																								
5	2012	ALL	Body	Passenger Presence System																																								
5	2012	ALL	Body	Personal Audio Link Module																																								
5	2012	ALL	Body	Base Radio																																								
5	2012	ALL	Body	Uplevel Radio																																								
5	2012	ALL	Body	Supplemental Inflatable Restraint																																								
5	2012	ALL	Body	Theft Deterrent Module																																								
5	2012	ALL	Body	Vehicle Comm. Interface Module								V																																
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
5	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
5	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																								
5	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																								
5	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
5	2015	Canyon	Powertrain	Chassis Control Module																																								
5	2015	Canyon	Powertrain	Transfer Case Control Module																																								
5	2015	Canyon	Chassis	Electronic Brake Control Module																																								
5	2015	Canyon	Chassis	Power Steering Control Module																																								
5	2015	Canyon	Body	Body Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
5	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
5	2015	Canyon	Body	Passenger Presence Module																																								
5	2015	Canyon	Body	Radio																																								
5	2015	Canyon	Body	Amplifier																																								
5	2015	Canyon	Body	Human Machine Interface Control Module																																								
5	2015	Canyon	Body	Telematics Communication Interface Control Module																																								
5	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																								
5	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																								
5	2015	Canyon	Body	Parking Assist Control Module																																								
5	2015	Canyon	Body	Frontview Camera Module																																								
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
5	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
5	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
5	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																								
5	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																								
5	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																								
5	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
5	2016	Canyon	Powertrain	Transfer Case Control Module																																								
5	2016	Canyon	Chassis	Electronic Brake Control Module																																								
5	2016	Canyon	Chassis	Power Steering Control Module																																								
5	2016	Canyon	Body	Body Control Module																																								
5	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
5	2016	Canyon	Body	Passenger Presence Module																																								
5	2016	Canyon	Body	Trailer Interface Control Module																																								
5	2016	Canyon	Body	Radio																																								
5	2016	Canyon	Body	Amplifier																																								
5	2016	Canyon	Body	Human Machine Interface Control Module																																								
5	2016	Canyon	Body	Telematics Communication Interface Control Module																																								
5	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																								
5	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																								
5	2016	Canyon	Body	Frontview Camera Module																																								
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
6	2011	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																								
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
6	2011	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																								
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																								
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																								
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																								
6	2011	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																								
6	2011	ALL	Chassis	Electronic Brake Control Module																																								
6	2011	ALL	Body	Body Control Module																																								
6	2011	ALL	Body	Digital Radio Receiver																																								
6	2011	ALL	Body	Generator Battery Control Module																																								
6	2011	ALL	Body	Instrument Panel Cluster																																								
6	2011	ALL	Body	Passenger Presence System																																								
6	2011	ALL	Body	Personal Audio Link Module																																								
6	2011	ALL	Body	Base Radio																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
6	2011	ALL	Body	Uplevel Radio																																								
6	2011	ALL	Body	Supplemental Inflatable Restraint																																								
6	2011	ALL	Body	Theft Deterrent Module																																								
6	2011	ALL	Body	Vehicle Comm. Interface Module								V																																
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Engine Control Module																																								
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transmission Control Module																																								
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Fuel Pump Control Module																																								
6	2012	ALL	Powertrain	(9)2.9L L4 LLV Transfer Case Control Module																																								
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Engine Control Module																																								
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transmission Control Module																																								
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Fuel Pump Control Module																																								
6	2012	ALL	Powertrain	(E)3.7L L5 LLR Transfer Case Control Module																																								
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Engine Control Module																																								
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transmission Control Module																																								
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Fuel Pump Control Module																																								
6	2012	ALL	Powertrain	(P)5.3L V8 LH9 Transfer Case Control Module																																								
6	2012	ALL	Chassis	Electronic Brake Control Module																																								
6	2012	ALL	Body	Body Control Module																																								
6	2012	ALL	Body	Digital Radio Receiver																																								
6	2012	ALL	Body	Generator Battery Control Module																																								
6	2012	ALL	Body	Instrument Panel Cluster																																								
6	2012	ALL	Body	Passenger Presence System																																								
6	2012	ALL	Body	Personal Audio Link Module																																								
6	2012	ALL	Body	Base Radio																																								
6	2012	ALL	Body	Uplevel Radio																																								
6	2012	ALL	Body	Supplemental Inflatable Restraint																																								
6	2012	ALL	Body	Theft Deterrent Module																																								
6	2012	ALL	Body	Vehicle Comm. Interface Module								V																																
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
6	2015	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								
6	2015	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Automatic Transmission																																								
6	2015	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module Manual Transmission																																								
6	2015	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
6	2015	Canyon	Powertrain	Chassis Control Module																																								
6	2015	Canyon	Powertrain	Transfer Case Control Module																																								
6	2015	Canyon	Chassis	Electronic Brake Control Module																																								
6	2015	Canyon	Chassis	Power Steering Control Module																																								
6	2015	Canyon	Body	Body Control Module																																								
6	2015	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
6	2015	Canyon	Body	Passenger Presence Module																																								
6	2015	Canyon	Body	Radio																																								
6	2015	Canyon	Body	Amplifier																																								
6	2015	Canyon	Body	Human Machine Interface Control Module																																								
6	2015	Canyon	Body	Telematics Communication Interface Control Module																																								
6	2015	Canyon	Body	HVAC Control Module Auto Single (C68)																																								
6	2015	Canyon	Body	HVAC Control Module Manual Single (C67)																																								
6	2015	Canyon	Body	Parking Assist Control Module																																								
6	2015	Canyon	Body	Frontview Camera Module																																								
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Automatic Transmission																																								
6	2016	Canyon	Powertrain	(A) 2.5L LCV Engine Control Module Manual Transmission																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
6	2016	Canyon	Powertrain	(A) 2.5L LCV Transmission Control Module																																								
6	2016	Canyon	Powertrain	(1) 2.8L LWN Engine Control Module																																								
6	2016	Canyon	Powertrain	(1) 2.8L LWN Transmission Control Module																																								
6	2016	Canyon	Powertrain	(3) 3.6L LFX Engine Control Module																																								
6	2016	Canyon	Powertrain	(3) 3.6L LFX Transmission Control Module																																								
6	2016	Canyon	Powertrain	Transfer Case Control Module																																								
6	2016	Canyon	Chassis	Electronic Brake Control Module																																								
6	2016	Canyon	Chassis	Power Steering Control Module																																								
6	2016	Canyon	Body	Body Control Module																																								
6	2016	Canyon	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
6	2016	Canyon	Body	Passenger Presence Module																																								
6	2016	Canyon	Body	Trailer Interface Control Module																																								
6	2016	Canyon	Body	Radio																																								
6	2016	Canyon	Body	Amplifier																																								
6	2016	Canyon	Body	Human Machine Interface Control Module																																								
6	2016	Canyon	Body	Telematics Communication Interface Control Module																																								
6	2016	Canyon	Body	HVAC Control Module Auto Single (C68)																																								
6	2016	Canyon	Body	HVAC Control Module Manual Single (C67)																																								
6	2016	Canyon	Body	Frontview Camera Module																																								
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
7	2011	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
7	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
7	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
7	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
7	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
7	2011	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
7	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
7	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
7	2011	Express/Savana	Body	Body Control Module																																								
7	2011	Express/Savana	Body	Digital Radio Receiver																																								
7	2011	Express/Savana	Body	Instrument Panel Cluster																																								
7	2011	Express/Savana	Body	Passenger Presence System																																								
7	2011	Express/Savana	Body	Radio																																								
7	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																								
7	2011	Express/Savana	Body	Rollover Sensor																																								
7	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																								
7	2011	Express/Savana	Body	Theft Deterrent Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
7	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
7	2011	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
7	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
7	2011	Express Access/Savana Pro	Body	Body Control Module																																								
7	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																								
7	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
7	2011	Express Access/Savana Pro	Body	Passenger Presence System																																								
7	2011	Express Access/Savana Pro	Body	Radio																																								
7	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
7	2011	Express Access/Savana Pro	Body	Rollover Sensor																																								
7	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
7	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
7	2012	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
7	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
7	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
7	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
7	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
7	2012	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
7	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
7	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
7	2012	Express/Savana	Body	Body Control Module																																								
7	2012	Express/Savana	Body	Digital Radio Receiver																																								
7	2012	Express/Savana	Body	Instrument Panel Cluster																																								
7	2012	Express/Savana	Body	Passenger Presence System																																								
7	2012	Express/Savana	Body	Radio																																								
7	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																								
7	2012	Express/Savana	Body	Rollover Sensor																																								
7	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																								
7	2012	Express/Savana	Body	Theft Deterrent Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
7	2012	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
7	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
7	2012	Express Access/Savana Pro	Body	Body Control Module																																								
7	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																								
7	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
7	2012	Express Access/Savana Pro	Body	Passenger Presence System																																								
7	2012	Express Access/Savana Pro	Body	Radio																																								
7	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
7	2012	Express Access/Savana Pro	Body	Rollover Sensor																																								
7	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
7	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
7	2013	Express/Savana	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
7	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
7	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
7	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
7	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
7	2013	Express/Savana	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
7	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
7	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
7	2013	Express/Savana	Body	Body Control Module																																								
7	2013	Express/Savana	Body	Digital Radio Receiver																																								
7	2013	Express/Savana	Body	Instrument Panel Cluster																																								
7	2013	Express/Savana	Body	Passenger Presence System																																								
7	2013	Express/Savana	Body	Radio																																								
7	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																								
7	2013	Express/Savana	Body	Rollover Sensor																																								
7	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																								
7	2013	Express/Savana	Body	Theft Deterrent Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Engine Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(X)4.3L V6 LU3 Transmission Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Auxiliary Heater Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Engine Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Glow Plug Control Module																																								
7	2013	Express Access/Savana Pro	Powertrain	(L)6.6L V8 LGH Diesel Transmission Control Module																																								
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
7	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
7	2013	Express Access/Savana Pro	Body	Body Control Module																																								
7	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																								
7	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
7	2013	Express Access/Savana Pro	Body	Navigation Radio																																								
7	2013	Express Access/Savana Pro	Body	Park Assist Module																																								
7	2013	Express Access/Savana Pro	Body	Passenger Presence System																																								
7	2013	Express Access/Savana Pro	Body	Radio																																								
7	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
7	2013	Express Access/Savana Pro	Body	Rollover Sensor																																								
7	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
7	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
7	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																								
7	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																								
7	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																								
7	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																								
7	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																								
7	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																								
7	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																								
7	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																								
7	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
7	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
7	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
7	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								
7	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
7	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
7	2014	Savana	Chassis	Electronic Brake Control Module																																								
7	2014	Savana	Body	Body Control Module																																								
7	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
7	2014	Savana	Body	Passenger Presence Module																																								
7	2014	Savana	Body	Rollover Sensor Module																																								
7	2014	Savana	Body	Instrument Cluster																																								
7	2014	Savana	Body	Chime Alarm Control Module																																								
7	2014	Savana	Body	Base Radio																																								
7	2014	Savana	Body	Navigation Radio																																								
7	2014	Savana	Body	Uplevel Radio																																								
7	2014	Savana	Body	Digital Radio Receiver Control Module																																								
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																								
7	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
7	2014	Savana	Body	Auxiliary Heater Control Module																																								
7	2014	Savana	Body	Remote Control Door Lock Receiver																																								
7	2014	Savana	Body	Parking Assist Control Module																																								
7	2014	Savana	Body	Theft Deterrent Module																																								
7	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																								
7	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																								
7	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																								
7	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
7	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
7	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
7	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								
7	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
7	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
7	2015	Savana	Chassis	Electronic Brake Control Module																																								
7	2015	Savana	Body	Body Control Module																																								
7	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
7	2015	Savana	Body	Rollover Sensor Module																																								
7	2015	Savana	Body	Instrument Cluster																																								
7	2015	Savana	Body	Digital Radio Receiver Control Module																																								
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																								
7	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																								
7	2015	Savana	Body	Auxiliary Heater Control Module																																								
7	2015	Savana	Body	Remote Control Door Lock Receiver																																								
7	2015	Savana	Body	Parking Assist Control Module																																								
7	2015	Savana	Body	Theft Deterrent Module																																								
7	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																								
7	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																								
7	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																								
7	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
7	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
7	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
7	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								
7	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
7	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
7	2016	Savana	Chassis	Electronic Brake Control Module																																								
7	2016	Savana	Body	Body Control Module																																								
7	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
7	2016	Savana	Body	Instrument Cluster																																								
7	2016	Savana	Body	Chime Alarm Control Module																																								
7	2016	Savana	Body	Digital Radio Receiver Control Module																																								
7	2016	Savana	Body	Telematics Communication Interface Control Module																																								
7	2016	Savana	Body	Auxiliary Heater Control Module																																								
7	2016	Savana	Body	Remote Control Door Lock Receiver																																								
7	2016	Savana	Body	Parking Assist Control Module																																								
7	2016	Savana	Body	Theft Deterrent Module																																								
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
8	2011	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
8	2011	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
8	2011	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
8	2011	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
8	2011	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
8	2011	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
8	2011	Express/Savana	Body	Body Control Module																																								
8	2011	Express/Savana	Body	Digital Radio Receiver																																								
8	2011	Express/Savana	Body	Instrument Panel Cluster																																								
8	2011	Express/Savana	Body	Passenger Presence System																																								
8	2011	Express/Savana	Body	Radio																																								
8	2011	Express/Savana	Body	Remote Control Door Lock Receiver																																								
8	2011	Express/Savana	Body	Rollover Sensor																																								
8	2011	Express/Savana	Body	Supplemental Inflatable Restraint																																								
8	2011	Express/Savana	Body	Theft Deterrent Module																																								
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
8	2011	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
8	2011	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
8	2011	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
8	2011	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
8	2011	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
8	2011	Express Access/Savana Pro	Body	Body Control Module																																								
8	2011	Express Access/Savana Pro	Body	Digital Radio Receiver																																								
8	2011	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
8	2011	Express Access/Savana Pro	Body	Passenger Presence System																																								
8	2011	Express Access/Savana Pro	Body	Radio																																								
8	2011	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
8	2011	Express Access/Savana Pro	Body	Rollover Sensor																																								
8	2011	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
8	2011	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
8	2012	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
8	2012	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
8	2012	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
8	2012	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
8	2012	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
8	2012	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
8	2012	Express/Savana	Body	Body Control Module																																								
8	2012	Express/Savana	Body	Digital Radio Receiver																																								
8	2012	Express/Savana	Body	Instrument Panel Cluster																																								
8	2012	Express/Savana	Body	Passenger Presence System																																								
8	2012	Express/Savana	Body	Radio																																								
8	2012	Express/Savana	Body	Remote Control Door Lock Receiver																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
8	2012	Express/Savana	Body	Rollover Sensor																																								
8	2012	Express/Savana	Body	Supplemental Inflatable Restraint																																								
8	2012	Express/Savana	Body	Theft Deterrent Module																																								
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
8	2012	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
8	2012	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
8	2012	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
8	2012	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
8	2012	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
8	2012	Express Access/Savana Pro	Body	Body Control Module																																								
8	2012	Express Access/Savana Pro	Body	Digital Radio Receiver																																								
8	2012	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
8	2012	Express Access/Savana Pro	Body	Passenger Presence System																																								
8	2012	Express Access/Savana Pro	Body	Radio																																								
8	2012	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
8	2012	Express Access/Savana Pro	Body	Rollover Sensor																																								
8	2012	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
8	2012	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
8	2013	Express/Savana	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
8	2013	Express/Savana	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								
8	2013	Express/Savana	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
8	2013	Express/Savana	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
8	2013	Express/Savana	Chassis	Electronic Brake Control Module With VSES																																								
8	2013	Express/Savana	Chassis	Electronic Brake Control Module Without VSES																																								
8	2013	Express/Savana	Body	Body Control Module																																								
8	2013	Express/Savana	Body	Digital Radio Receiver																																								
8	2013	Express/Savana	Body	Instrument Panel Cluster																																								
8	2013	Express/Savana	Body	Navigation Radio																																								
8	2013	Express/Savana	Body	Park Assist Module																																								
8	2013	Express/Savana	Body	Passenger Presence System																																								
8	2013	Express/Savana	Body	Radio																																								
8	2013	Express/Savana	Body	Remote Control Door Lock Receiver																																								
8	2013	Express/Savana	Body	Rollover Sensor																																								
8	2013	Express/Savana	Body	Supplemental Inflatable Restraint																																								
8	2013	Express/Savana	Body	Theft Deterrent Module																																								
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Engine Control Module																																								
8	2013	Express Access/Savana Pro	Powertrain	(A)4.8L V8 L20 Transmission Control Module																																								
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Engine Control Module																																								
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Fuel Pump Control Module																																								
8	2013	Express Access/Savana Pro	Powertrain	(4)5.3L V8 LMF Transmission Control Module																																								
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Engine Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
8	2013	Express Access/Savana Pro	Powertrain	(G)6.0L V8 L96 Transmission Control Module																																								
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Engine Control Module																																								
8	2013	Express Access/Savana Pro	Powertrain	(B)6.0L V8 LC8 Transmission Control Module																																								
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module With VSES																																								
8	2013	Express Access/Savana Pro	Chassis	Electronic Brake Control Module Without VSES																																								
8	2013	Express Access/Savana Pro	Body	Body Control Module																																								
8	2013	Express Access/Savana Pro	Body	Digital Radio Receiver																																								
8	2013	Express Access/Savana Pro	Body	Instrument Panel Cluster																																								
8	2013	Express Access/Savana Pro	Body	Navigation Radio																																								
8	2013	Express Access/Savana Pro	Body	Park Assist Module																																								
8	2013	Express Access/Savana Pro	Body	Passenger Presence System																																								
8	2013	Express Access/Savana Pro	Body	Radio																																								
8	2013	Express Access/Savana Pro	Body	Remote Control Door Lock Receiver																																								
8	2013	Express Access/Savana Pro	Body	Rollover Sensor																																								
8	2013	Express Access/Savana Pro	Body	Supplemental Inflatable Restraint																																								
8	2013	Express Access/Savana Pro	Body	Theft Deterrent Module																																								
8	2014	Savana	Powertrain	(X) 4.3L LU3 Engine Control Module																																								
8	2014	Savana	Powertrain	(X) 4.3L LU3 Transmission Control Module																																								
8	2014	Savana	Powertrain	(A) 4.8L L20 Engine Control Module																																								
8	2014	Savana	Powertrain	(A) 4.8L L20 Transmission Control Module																																								
8	2014	Savana	Powertrain	(4) 5.3L LMF Engine Control Module																																								
8	2014	Savana	Powertrain	(4) 5.3L LMF Chassis Control Module																																								
8	2014	Savana	Powertrain	(4) 5.3L LMF Transmission Control Module																																								
8	2014	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																								
8	2014	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
8	2014	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
8	2014	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
8	2014	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								
8	2014	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
8	2014	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
8	2014	Savana	Chassis	Electronic Brake Control Module																																								
8	2014	Savana	Body	Body Control Module																																								
8	2014	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
8	2014	Savana	Body	Passenger Presence Module																																								
8	2014	Savana	Body	Rollover Sensor Module																																								
8	2014	Savana	Body	Instrument Cluster																																								
8	2014	Savana	Body	Chime Alarm Control Module																																								
8	2014	Savana	Body	Base Radio																																								
8	2014	Savana	Body	Navigation Radio																																								
8	2014	Savana	Body	Uplevel Radio																																								
8	2014	Savana	Body	Digital Radio Receiver Control Module																																								
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 9																																								
8	2014	Savana	Body	Telematics Communication Interface Control Module Version 10																																								
8	2014	Savana	Body	Auxiliary Heater Control Module																																								
8	2014	Savana	Body	Remote Control Door Lock Receiver																																								
8	2014	Savana	Body	Parking Assist Control Module																																								
8	2014	Savana	Body	Theft Deterrent Module																																								
8	2015	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																								
8	2015	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																								
8	2015	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																								
8	2015	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
8	2015	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
8	2015	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
8	2015	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								
8	2015	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
8	2015	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
8	2015	Savana	Chassis	Electronic Brake Control Module																																								
8	2015	Savana	Body	Body Control Module																																								
8	2015	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
8	2015	Savana	Body	Rollover Sensor Module																																								
8	2015	Savana	Body	Instrument Cluster																																								
8	2015	Savana	Body	Digital Radio Receiver Control Module																																								
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 9																																								
8	2015	Savana	Body	Telematics Communication Interface Control Module Version 10																																								
8	2015	Savana	Body	Auxiliary Heater Control Module																																								
8	2015	Savana	Body	Remote Control Door Lock Receiver																																								
8	2015	Savana	Body	Parking Assist Control Module																																								
8	2015	Savana	Body	Theft Deterrent Module																																								
8	2016	Savana	Powertrain	(F) 4.8L L20 Engine Control Module																																								
8	2016	Savana	Powertrain	(F) 4.8L L20 Transmission Control Module																																								
8	2016	Savana	Powertrain	(G) 6.0L L96 Engine Control Module																																								
8	2016	Savana	Powertrain	(G) 6.0L L96 Transmission Control Module																																								
8	2016	Savana	Powertrain	(B) 6.0L LC8 Engine Control Module																																								
8	2016	Savana	Powertrain	(B) 6.0L LC8 Transmission Control Module																																								
8	2016	Savana	Powertrain	(L) 6.6L LGH Engine Control Module																																								
8	2016	Savana	Powertrain	(L) 6.6L LGH Glow Plug Control Module																																								
8	2016	Savana	Powertrain	(L) 6.6L LGH Transmission Control Module																																								
8	2016	Savana	Chassis	Electronic Brake Control Module																																								
8	2016	Savana	Body	Body Control Module																																								
8	2016	Savana	Body	Inflatable Restraint Sensing and Diagnostic Module																																								
8	2016	Savana	Body	Instrument Cluster																																								
8	2016	Savana	Body	Chime Alarm Control Module																																								
8	2016	Savana	Body	Digital Radio Receiver Control Module																																								
8	2016	Savana	Body	Telematics Communication Interface Control Module																																								
8	2016	Savana	Body	Auxiliary Heater Control Module																																								
8	2016	Savana	Body	Remote Control Door Lock Receiver																																								
8	2016	Savana	Body	Parking Assist Control Module																																								
8	2016	Savana	Body	Theft Deterrent Module																																								
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																								
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																								
ALL	2004	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																								
ALL	2004	ALL	Chassis	ABS																																								
ALL	2004	ALL	Chassis	Air Suspension																							V																	
ALL	2004	ALL	Body	Amplifier (Bose)																																								
ALL	2004	ALL	Body	Body Control Module																																								
ALL	2004	ALL	Body	Digital Radio Receiver																																								
ALL	2004	ALL	Body	Driver Door Module																																								
ALL	2004	ALL	Body	Driver Seat Module																																								
ALL	2004	ALL	Body	Heating and Air Conditioning																																								
ALL	2004	ALL	Body	Instrument Panel Cluster																																								
ALL	2004	ALL	Body	OnStar																																								
ALL	2004	ALL	Body	Passenger Door Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
ALL	2004	ALL	Body	Uplevel Radio																																								
ALL	2004	ALL	Body	Navigation Radio																																								
ALL	2004	ALL	Body	Rear Seat Audio																																								
ALL	2004	ALL	Body	Supplemental Inflatable Restraint																																								
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																								
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																								
ALL	2005	ALL	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																								
ALL	2005	ALL	Chassis	ABS																																								
ALL	2005	ALL	Chassis	Air Suspension																							V																	
ALL	2005	ALL	Body	Body Control Module																																								
ALL	2005	ALL	Body	Digital Radio Receiver																																								
ALL	2005	ALL	Body	Driver Door Module (SUV)																																								
ALL	2005	ALL	Body	Driver Door Module (SUT)																																								
ALL	2005	ALL	Body	Driver Seat Module																																								
ALL	2005	ALL	Body	Heating and Air Conditioning																																								
ALL	2005	ALL	Body	Instrument Panel Cluster																																								
ALL	2005	ALL	Body	Passenger Door Module																																								
ALL	2005	ALL	Body	Uplevel Radio																																								
ALL	2005	ALL	Body	Navigation Radio																																								
ALL	2005	ALL	Body	Rear Seat Audio																																								
ALL	2005	ALL	Body	Supplemental Inflatable Restraint																																								
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																								
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																								
ALL	2006	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																								
ALL	2006	H2	Chassis	ABS																																								
ALL	2006	H2	Chassis	Air Suspension																							V																	
ALL	2006	H2	Body	Body Control Module																																								
ALL	2006	H2	Body	Digital Radio Receiver																																								
ALL	2006	H2	Body	Driver Door Module (SUV)																																								
ALL	2006	H2	Body	Driver Door Module (SUT)																																								
ALL	2006	H2	Body	Driver Seat Module																																								
ALL	2006	H2	Body	Heating and Air Conditioning																																								
ALL	2006	H2	Body	Instrument Panel Cluster																																								
ALL	2006	H2	Body	Passenger Door Module																																								
ALL	2006	H2	Body	Uplevel Radio																																								
ALL	2006	H2	Body	Navigation Radio																																								
ALL	2006	H2	Body	Rear Seat Audio																																								
ALL	2006	H2	Body	Supplemental Inflatable Restraint																																								
ALL	2006	H3	Powertrain	Engine Control Module																																								
ALL	2006	H3	Powertrain	Transmission Control Module																																								
ALL	2006	H3	Powertrain	Transfer Case Control Module																																								
ALL	2006	H3	Chassis	Antilock Brake System																																								
ALL	2006	H3	Body	Body Control Module																																								
ALL	2006	H3	Body	Digital Radio Receiver																																								
ALL	2006	H3	Body	Instrument Panel Cluster																																								
ALL	2006	H3	Body	Uplevel Radio																																								
ALL	2006	H3	Body	Navigation Radio																																								
ALL	2006	H3	Body	Supplemental Inflatable Restraint																																								
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Engine Control Module																																								
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transmission Control Module																																								
ALL	2007	H2	Powertrain	(U) 6.0L V8 LQ4 Transfer Case Control Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
ALL	2007	H2	Chassis	ABS																																								
ALL	2007	H2	Chassis	Air Suspension																							V																	
ALL	2007	H2	Body	Amplifier (Bose)																																								
ALL	2007	H2	Body	Body Control Module																																								
ALL	2007	H2	Body	Digital Radio Receiver																																								
ALL	2007	H2	Body	Driver Door Module (SUV)																																								
ALL	2007	H2	Body	Driver Door Module (SUT)																																								
ALL	2007	H2	Body	Driver Seat Module																																								
ALL	2007	H2	Body	HVAC Control Module																																								
ALL	2007	H2	Body	Instrument Panel Cluster																																								
ALL	2007	H2	Body	Passenger Door Module							V																	V																
ALL	2007	H2	Body	Uplevel Radio																																								
ALL	2007	H2	Body	Navigation Radio																																								
ALL	2007	H2	Body	Rear Seat Audio																																								
ALL	2007	H2	Body	Supplemental Inflatable Restraint																																								
ALL	2007	H2	Body	Vehicle Comm. Interface Module																																								
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																								
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																								
ALL	2007	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																								
ALL	2007	H3	Chassis	EBCM																																								
ALL	2007	H3	Body	Body Control Module (5GT)																																								
ALL	2007	H3	Body	Body Control Module (ADM)																																								
ALL	2007	H3	Body	Digital Radio Receiver																																								
ALL	2007	H3	Body	Generator Battery Control Module																																								
ALL	2007	H3	Body	Instrument Panel Cluster																																								
ALL	2007	H3	Body	Personal Audio Link Module																																								
ALL	2007	H3	Body	Uplevel Radio																																								
ALL	2007	H3	Body	Navigation Radio																																								
ALL	2007	H3	Body	Supplemental Inflatable Restraint																																								
ALL	2007	H3	Body	Vehicle Comm. Interface Module																																								
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																								
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																								
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																								
ALL	2008	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																								
ALL	2008	H2	Chassis	Air SCM																									V															
ALL	2008	H2	Chassis	EBCM																										V														
ALL	2008	H2	Body	Amplifier (Bose)																																								
ALL	2008	H2	Body	Body Control Module																																								
ALL	2008	H2	Body	Digital Radio Receiver																																								
ALL	2008	H2	Body	Driver Door Switch																																								
ALL	2008	H2	Body	HVAC Control Module																																								
ALL	2008	H2	Body	Instrument Panel Cluster																																								
ALL	2008	H2	Body	Memory Seat Module																																								
ALL	2008	H2	Body	Passenger Door Switch																																								
ALL	2008	H2	Body	Radio																																								
ALL	2008	H2	Body	Rear Heated Seat Module																																								
ALL	2008	H2	Body	Rear HVAC/RSA																																								
ALL	2008	H2	Body	Rollover Sensor																																								
ALL	2008	H2	Body	Supplemental Inflatable Restraint																																								
ALL	2008	H2	Body	Theft Deterrent Module																																								
ALL	2008	H2	Body	Vehicle Comm. Interface Module																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GT)																																									
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																									
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																									
ALL	2008	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module																																									
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module																																									
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																									
ALL	2008	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module																																									
ALL	2008	H3	Chassis	EBCM																																									
ALL	2008	H3	Body	Body Control Module (5GT)																																									
ALL	2008	H3	Body	Body Control Module (ADM)																																									
ALL	2008	H3	Body	Digital Radio Receiver																																									
ALL	2008	H3	Body	Generator Battery Control Module																																									
ALL	2008	H3	Body	Instrument Panel Cluster																																									
ALL	2008	H3	Body	Personal Audio Link Module																																									
ALL	2008	H3	Body	Uplevel Radio																																									
ALL	2008	H3	Body	Navigation Radio																																									
ALL	2008	H3	Body	Supplemental Inflatable Restraint																																									
ALL	2008	H3	Body	Theft Deterrent Module																																									
ALL	2008	H3	Body	Vehicle Comm. Interface Module																																									
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																									
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																									
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																									
ALL	2009	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																									
ALL	2009	H2	Chassis	Air SCM																									V																
ALL	2009	H2	Chassis	EBCM																										V															
ALL	2009	H2	Body	Amplifier (Bose)																																									
ALL	2009	H2	Body	Body Control Module																																									
ALL	2009	H2	Body	Digital Radio Receiver																																									
ALL	2009	H2	Body	Driver Door Switch																																									
ALL	2009	H2	Body	HVAC Control Module																																									
ALL	2009	H2	Body	Instrument Panel Cluster																																									
ALL	2009	H2	Body	Memory Seat Module																																									
ALL	2009	H2	Body	Passenger Door Switch																																									
ALL	2009	H2	Body	Radio																																									
ALL	2009	H2	Body	Rear Heated Seat Module																																									
ALL	2009	H2	Body	Rear HVAC/RSA																																									
ALL	2009	H2	Body	Rollover Sensor																																									
ALL	2009	H2	Body	Supplemental Inflatable Restraint																																									
ALL	2009	H2	Body	Theft Deterrent Module																																									
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																									
ALL	2009	H2	Body	Vehicle Comm. Interface Module																																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (5GN/5GT)																																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module (ADM)																																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																									
ALL	2009	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																									
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (NO)																																									
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Engine Control Module Aux. Cooling Fan (YES)																																									
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Fuel Pump Control Module																																									
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transmission Control Module																																									

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (YES)																																								
ALL	2009	H3	Powertrain	(L) 5.3L V8 LH8 Transfer Case Control Module Front Differential Lock (NO)																																								
ALL	2009	H3	Chassis	EBCM																																								
ALL	2009	H3	Body	Body Control Module (5GN/5GT)																																								
ALL	2009	H3	Body	Body Control Module (ADM)																																								
ALL	2009	H3	Body	Digital Radio Receiver																																								
ALL	2009	H3	Body	Generator Battery Control Module																																								
ALL	2009	H3	Body	Instrument Panel Cluster																																								
ALL	2009	H3	Body	Personal Audio Link Module																																								
ALL	2009	H3	Body	Uplevel Radio																																								
ALL	2009	H3	Body	Navigation Radio																																								
ALL	2009	H3	Body	Supplemental Inflatable Restraint																																								
ALL	2009	H3	Body	Theft Deterrent Module																																								
ALL	2009	H3	Body	Vehicle Comm. Interface Module								V																																
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Engine Control Module																																								
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Fuel Pump Control Module																																								
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transmission Control Module																																								
ALL	2010	H2	Powertrain	(2) 6.2L V8 L9H Transfer Case Control Module																																								
ALL	2010	H2	Chassis	Air SCM																									V															
ALL	2010	H2	Chassis	EBCM																										V														
ALL	2010	H2	Body	Amplifier (Bose)																																								
ALL	2010	H2	Body	Body Control Module																																								
ALL	2010	H2	Body	Digital Radio Receiver																																								
ALL	2010	H2	Body	Driver Door Switch																																								
ALL	2010	H2	Body	HVAC Control Module																																								
ALL	2010	H2	Body	Instrument Panel Cluster																																								
ALL	2010	H2	Body	Memory Seat Module																																								
ALL	2010	H2	Body	Passenger Door Switch																																								
ALL	2010	H2	Body	Personal Audio Link Module																											V													
ALL	2010	H2	Body	Radio																																								
ALL	2010	H2	Body	Rear Heated Seat Module																																								
ALL	2010	H2	Body	Rear HVAC/RSA																																								
ALL	2010	H2	Body	Rollover Sensor																																								
ALL	2010	H2	Body	Supplemental Inflatable Restraint																																								
ALL	2010	H2	Body	Theft Deterrent Module																																								
ALL	2010	H2	Body	Vehicle Comm. Interface Module																																								
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Engine Control Module																																								
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Fuel Pump Control Module																																								
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transmission Control Module																																								
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (YES)																																								
ALL	2010	H3	Powertrain	(E) 3.7L L5 LLR Transfer Case Control Module Front Differential Lock (NO)																																								
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Engine Control Module																																								
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Fuel Pump Control Module																																								
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transmission Control Module																																								
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (YES)																																								
ALL	2010	H3	Powertrain	(P) 5.3L V8 LH9 Transfer Case Control Module Front Differential Lock (NO)																																								
ALL	2010	H3	Chassis	EBCM																																								
ALL	2010	H3	Body	Body Control Module																																								
ALL	2010	H3	Body	Digital Radio Receiver																																								
ALL	2010	H3	Body	Generator Battery Control Module																																								
ALL	2010	H3	Body	Instrument Panel Cluster																																								

Engine type	Year	Model	System 1	System 2	BCM Setup	P/N Position Learn Procedure	HVAC Sensors 2	Power window motor programming	A/C Request Withheld	Recalibrate All Motors	TPM Option Enable	Bluetooth Status	Instant OAT Update	Odometer Data	Invalidate All Fobs	Next Available Slot	TPM Learn Mode	Controller Information 1	Controller Information 2	DRP/ABS/TCS Data	Setup RFA	Setup IPC	Setup New VTD Module	Clear DTC Information	Engine Cooling	Engine Electrical	Calibrate Trim Height	Spare Tire Monitoring Disable	Air SCM Data	EBCM Data Analysis	Radio RPO Selection	Audible Reminders Data	Retained Accessory Power	Tire Pressure Identification	VTD Data	Middle East Region Mode	Optional Modules	Region Code Options	Cooling Data	Setup New RCDLR	All Wheel Drive Data	Chime Settings	Seek/Scan Sensitivity Levels	Theftlock LED
ALL	2010	H3	Body	Personal Audio Link Module																																								
ALL	2010	H3	Body	Uplevel Radio																																								
ALL	2010	H3	Body	Navigation Radio																																								
ALL	2010	H3	Body	Supplemental Inflatable Restraint																																								
ALL	2010	H3	Body	Theft Deterrent Module																																								
ALL	2010	H3	Body	Vehicle Comm. Interface Module								V																																

Vehicle	System1	Type1	DTC	CURR	ACT	ECUINFOR	TWC Diagnose at Idle	Tooth Learned	O2 Feedback Diagnosis	Repair Bleeding	Read Injector Code	Write Injector
HAVAL H3/X240	Engine	Delphi MT 2002 EOBD ECU	V	V	V	V	V	V	V			
HAVAL H3/X240	ABS	Bosch ABS	V	V	V	V				V		
HAVAL H3/X240	SRS	Jingheng SRS	V	V								
HAVAL H3/X240	SRS	Bosch SRS	V			V						
HAVAL H3/X240	SRS	CH041 Autolive SRS	V	V		V						
HAVAL H3/X240	BCM	Delphi BCM	V	V	V	V						
HAVAL H3/X240	Immobilizer	Shanghai Immo	V	V		V						
HAVAL H5	Engine	Delphi MT 2002 EOBD ECU	V	V	V	V	V	V	V			
HAVAL H5	ABS	Bosch ABS	V	V	V	V				V		
HAVAL H5	SRS	Jingheng SRS	V	V								
HAVAL H5	SRS	Bosch SRS	V			V						
HAVAL H5	SRS	CH041 Autolive SRS	V	V		V						
HAVAL H5	BCM	Delphi BCM	V	V	V	V						
HAVAL H5	Immobilizer	Shanghai Immo	V	V		V						
Wingle/V240	Engine	Delphi MT 2002 EOBD ECU	V	V	V	V	V	V	V			
Wingle/V240	Engine	Bosch V50 Diesel Engine System	V	V	V	V						
Wingle/V240	Engine	Delphi Diesel Engine System	V	V	V	V					V	V
Wingle/V240	ABS	Bosch ABS	V	V	V	V				V		
Wingle/V240	SRS	Jingheng SRS	V	V								
Voleex C30	Engine	Union M797 EOBD	V	V	V	V	V	V	V			
Voleex C30	ABS	Bosch ABS	V	V	V	V				V		
Voleex C30	SRS	CH041 Autolive SRS	V	V		V						
Voleex C30	Immobilizer	Shanghai Immo	V	V		V						
Voleex C10	Engine	Union M797 EOBD	V	V	V	V	V	V	V			
Voleex C10	ABS	Bosch ABS	V	V	V	V				V		
Voleex C10	SRS	CH041 Autolive SRS	V	V		V						
Voleex C10	Immobilizer	Shanghai Immo	V	V		V						
Florid	Engine	Union M797 EOBD	V	V	V	V	V	V	V			
Florid	ABS	Bosch ABS	V	V	V	V				V		
Florid	SRS	CH041 Autolive SRS	V	V		V						
Florid	Immobilizer	Shanghai Immo	V	V		V						

Year	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	DPR Status Check	DPR Differential Pressure Check	DPR Forced Regeneration	Injector ID Code Verification	Injector Compensation	Injector Compensation(Replacing ECU)	Supply Pump Initializtion	Suction Air Volume Check	Check Turbocharger	DPR Status	Reset all DPR status	Forced DPR regeneration	Differential pressure check	Supply pump specification learning	Initialize intake throttle valve	Injector ID Code Registeration	DPR Status Reset	Supply Pump Learned Value - Initialization	VNT Check	Fuel Leak Check	EGR Check	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting	Frequency Of Mode Use	Clock Setup	Air Bleeder	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Registration	Injector ID code Read/Write (ECU change)	MAF Correction Data Check	MAF Correction Data Service Mode	MAF Correction Data Read/Write (ECU change)	Erasing the Learned Supply Pump	Q-Correction Data Check	Q-Correction Data Read/Write (ECU change)	Engine Start Number / Write (When replacing ECU)	Engine Start Number / Write (When replacing Starter)
16PIN CONNECTOR	Engine	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																
16PIN CONNECTOR	AT	V	V	V																																									
16PIN CONNECTOR	ProShift	V	V			V																									V	V														
16PIN CONNECTOR	FF Shift	V	V			V																																								
16PIN CONNECTOR	ABS	V	V	V	V																												V													
16PIN CONNECTOR	SRS Airbag(DUTRO/RANGER)	V	V	V																																									
16PIN CONNECTOR	SRS Airbag(PROFIA)	V	V	V																																									
16PIN CONNECTOR	Inverter	V	V			V																																								
16PIN CONNECTOR	Suspension	V	V			V																																								
16PIN CONNECTOR	Hybrid	V	V			V																																								
16PIN CONNECTOR	Battery	V	V			V																																								
16PIN CONNECTOR	Meter	V	V			V																																								
16PIN CONNECTOR	Adaptive Cruise Control/Lane departure warning/Autonomous Emergency Braking	V	V			V																																								
16PIN CONNECTOR	VCS	V	V			V																																								
12PIN CONNECTOR	Engine(J08C Pre-stroke Pump)	V	V																																											
12PIN CONNECTOR	Engine(J08C Electronic Governor)	V	V																																											
12PIN CONNECTOR	Engine(J07C Electronic Governor)	V	V																																											
12PIN CONNECTOR	Engine(Model FF/GD)	V	V																																											
12PIN CONNECTOR	SRS Airbag(RANGER PRO)	V	V																																											
12PIN CONNECTOR	SRS Airbag(SUPERDOLPHIN PROFIA)	V	V																																											
5PIN CONNECTOR	Engine(Model FF/GD)	V	V																																											
5PIN CONNECTOR	Engine(J08C(J-IV) EGR System with Mechanical Pump/Mechanical Governor))	V	V																																											
5PIN CONNECTOR	Engine(J08C(J-V) EGR System with Mechanical Pump/Mechanical Governor))	V	V																																											
5PIN CONNECTOR	Engine(K13C Common rail)	V	V																																											
5PIN CONNECTOR	Engine(P11C Common rail)	V	V																																											
5PIN CONNECTOR	Engine(F21C Electronic Governor)	V	V																																											
5PIN CONNECTOR	SRS Airbag(RANGER PRO)	V	V																																											
5PIN CONNECTOR	SRS Airbag(SUPERDOLPHIN PROFIA)	V	V																																											

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
Commodore/VR	Engine	V6/V8	V	V	V																																							
Commodore/VR	Transmission	A/T	V	V	V																																							
Commodore/VR	Chassis	ABS	V	V	V	V																																						
Commodore/VR	Body	SRS Airbag	V																																									
Commodore/VR	Body	BCM(Body control module)	V	V																																								
Commodore/VR	Body	TDM	V	V																																								
Commodore/VS	Engine	V6	V	V	V																																							
Commodore/VS	Engine	V8	V	V	V																																							
Commodore/VS	Transmission	V6 A/T	V	V	V																																							
Commodore/VS	Transmission	V8 A/T	V	V	V																																							
Commodore/VS	Chassis	ABS	V	V	V	V																																						
Commodore/VS	Body	SRS Airbag	V	V																																								
Commodore/VS	Body	BCM(Body control module)	V	V																																								
Commodore/VT(Include VSv8)	Engine	V6	V	V	V	V																																						
Commodore/VT(Include VSv8)	Engine	V8	V	V	V	V																																						
Commodore/VT(Include VSv8)	Engine	V8 GEN III	V	V	V																																							
Commodore/VT(Include VSv8)	Transmission	A/T	V	V	V	V																																						
Commodore/VT(Include VSv8)	Transmission	A/T GEN III	V	V	V																																							
Commodore/VT(Include VSv8)	Chassis	ABS	V	V	V	V																																						
Commodore/VT(Include VSv8)	Body	SRS Airbag	V	V		V																																						
Commodore/VT(Include VSv8)	Body	BCM(Body control module)	V	V	V	V																																						
Commodore/VT(Include VSv8)	Body	Instrument	V	V	V	V																																						
Commodore/VT(Include VSv8)	Body	PIM(Powertrain Interface Module)	V	V		V																																						
Commodore/VT(Include VSv8)	Body	Climate Control	V	V		V																																						
Commodore/VX	Engine	V6	V	V	V	V																																						
Commodore/VX	Engine	V6 Supercharged	V	V	V	V																																						
Commodore/VX	Engine	V8 GEN III	V	V	V																																							
Commodore/VX	Transmission	A/T	V	V	V	V																																						
Commodore/VX	Transmission	A/T GEN III	V	V	V																																							
Commodore/VX	Chassis	ABS	V	V	V	V																																						
Commodore/VX	Body	SRS Airbag	V	V		V																																						
Commodore/VX	Body	BCM(Body control module)	V	V	V	V																																						
Commodore/VX	Body	Instrument	V	V	V	V																																						
Commodore/VX	Body	PIM(Powertrain Interface Module)	V	V		V																																						
Commodore/VX	Body	Climate Control	V	V		V																																						
Commodore/VY	Engine	V6	V	V	V	V																																						
Commodore/VY	Engine	V6 Supercharged	V	V	V	V																																						
Commodore/VY	Engine	V8 GEN III	V	V	V																																							

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
Commodore/VY	Transmission	A/T	V	V	V	V																																						
Commodore/VY	Transmission	A/T GEN III	V	V	V																																							
Commodore/VY	Chassis	ABS	V	V	V	V																																						
Commodore/VY	Body	SRS Airbag	V	V		V																																						
Commodore/VY	Body	BCM(Body control module)	V	V	V	V																																						
Commodore/VY	Body	Instrument	V	V	V	V																																						
Commodore/VY	Body	PIM(Powertrain Interface Module)	V	V	V	V																																						
Commodore/VY	Body	Audio System	V	V		V																																						
Commodore/VZ	Engine	V6	V	V	V	V																																						
Commodore/VZ	Engine	V6 Supercharged	V	V	V	V																																						
Commodore/VZ	Engine	V8 GEN III	V	V	V																																							
Commodore/VZ	Engine	V8 GEN IV	V	V	V	V	V																																					
Commodore/VZ	Transmission	A/T	V	V	V	V																																						
Commodore/VZ	Transmission	A/T GEN III	V	V	V																																							
Commodore/VZ	Chassis	ABS/TC/ESP8.0	V	V	V	V																																						
Commodore/VZ	Chassis	ABS/ETC	V	V	V	V																																						
Commodore/VZ	Body	SRS Airbag	V	V		V																																						
Commodore/VZ	Body	BCM(Body control module)	V	V	V	V																																						
Commodore/VZ	Body	PIM(Powertrain Interface Module)	V	V	V	V																																						
Commodore/VZ	Body	Instrument	V	V	V	V																																						
Commodore/VZ	Body	Audio System	V	V		V																																						
Commodore/VE	Engine	V6	V	V	V	V																																						
Commodore/VE	Engine	V8 GEN IV	V	V	V	V																																						
Commodore/VE	Transmission	A/T	V	V	V	V																																						
Commodore/VE	Chassis	EBCM(Electronic brake control module)	V	V	V	V																																						
Commodore/VE	Chassis	TPMS(Tyre pressure monitor system)	V	V				V																																				
Commodore/VE	Chassis	Fuel Pump Control	V	V	V	V																																						
Commodore/VE	Body	BCM(Body control module)	V	V		V																																						
Commodore/VE	Body	VTM(Theft deterrent module)	V	V				V																																				
Commodore/VE	Body	RFA(Remote function actuator)	V	V				V																																				
Commodore/VE	Body	SDM(SRS Airbag)	V	V																																								
Commodore/VE	Body	IPC(Instrument Panel Cluster)	V	V	V			V																																				
Commodore/VE	Body	HVAC(Heating Ventilating and Air Conditioning)	V	V	V																																							
Commodore/VE	Body	MSM	V	V																																								
Commodore/VE	Body	Parking Assist	V	V																																								
Commodore/VE	Body	AHL	V																																									
Commodore/VE	Infotainment System	Audio System	V	V	V	V		V																																				
Commodore/VE	Infotainment System	Rear Seat Entertainment	V	V																																								

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
VF Comodore	Powertrain	3.0L LFW(Beta)	V	V	V	V																																					
VF Comodore	Powertrain	3.6L LFX	V	V	V	V																																					
VF Comodore	Powertrain	6.2L LS3(Beta)	V	V	V	V																																					
VF Comodore	Powertrain	FICM(Fuel injector control module)	V			V																																					
VF Comodore	Powertrain	TCM(Transmission control unit)	V	V	V	V																																					
VF Comodore	Chassis	CCM(Chassis control module)	V	V	V	V																																					
VF Comodore	Chassis	EBCM(Electronic brake control module)	V	V	V	V																																	V	V			
VF Comodore	Chassis	PBCM(Parking brake control module)	V	V	V	V																													V	V	V	V					
VF Comodore	Chassis	PSCM(Power steering control module)	V	V		V																																					
VF Comodore	Chassis	SWASM(Steering wheel angle sensor module)	V			V																											V	V									
VF Comodore	Chassis	SCM(Suspension control module)	V			V																																					
VF Comodore	Body	Immobilizer																														V											
VF Comodore	Body	BCM(Body control module)	V	V	V	V																						V	V	V	V	V											
VF Comodore	Body	SDM(Inflatable restraint sensing and diagnostic module)	V	V		V																																					
VF Comodore	Body	IC(Instrument cluster)	V	V	V	V																				V																	
VF Comodore	Body	HDM(Head-up display module)	V	V	V	V																																					
VF Comodore	Body	RCP(Radio control panel)	V	V	V	V																			V	V																	
VF Comodore	Body	HVACCP(Heating Ventilating and Air Conditioning control panel)	V	V	V	V																			V																		
VF Comodore	Body	Radio	V	V	V	V																																					
VF Comodore	Body	HVAC(Heating Ventilating and Air Conditioning)	V	V	V	V																																					
VF Comodore	Body	RODCM(Right side object detection control module)	V		V	V																																					
VF Comodore	Body	LODCM(Left side object detection control module)	V		V	V																																					
VF Comodore	Body	Keyless	V	V		V																																					
VF Comodore	Body	PACM(Parking assist control module)	V	V	V	V																				V																	
VF Comodore	Body	FVCM(Front view camera module)	V			V																																					
VF Comodore	Body	SCCM(Steering column lock control module)	V			V																																					
YG Cruze		Engine	V	V	V	V																																					
YG Cruze		Transmission	V	V		V																																					
YG Cruze		ABS	V	V		V																																					
YG Cruze		EPS	V	V		V																																					
YG Cruze		Immobilizer	V	V		V																																					
YG Cruze		Airbag	V	V		V																																					
Cruze/Gasoline	Powertrain	Engine control module(1.4L LUJ)	V	V	V		V																																				
Cruze/Gasoline	Powertrain	Engine control module(1.8L 2H0)	V	V		V																																					
Cruze/Gasoline	Powertrain	Fuel pump control module	V	V		V																																					
Cruze/Gasoline	Powertrain	Transmission control module	V																																								
Cruze/Gasoline	Chassis	EBCM(Electronic brake control module)	V	V	V	V																																					
Cruze/Gasoline	Chassis	Multi-Axis acceleration sensor module	V			V																																					

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
Cruze/Gasoline	Chassis	Steering wheel angle sensor module	V			V																																						
Cruze/Gasoline	Chassis	Electrinic power steering control module	V			V																																						
Cruze/Gasoline	Body	Body control module	V	V	V	V																																						
Cruze/Gasoline	Body	Immobilizer																																										
Cruze/Gasoline	Body	SDM(Inflatable restraint sensing and diagnostic module)	V	V	V	V																																						
Cruze/Gasoline	Body	Passenger presence module	V																																									
Cruze/Gasoline	Body	Instrument panel cluster	V	V	V	V																																						
Cruze/Gasoline	Body	Auto Heating ventilating and air conditioning	V	V	V	V																																						
Cruze/Gasoline	Body	Manual Heating ventilating and air conditioning	V	V	V	V																																						
Cruze/Gasoline	Body	Front seat heating control module	V	V	V	V																																						
Cruze/Gasoline	Body	Park assist control module	V			V																																						
Cruze/Gasoline	Body	Passive entry passive start	V																																									
Cruze/Gasoline	Body	Steering column lock control module	V																																									
Cruze/Gasoline	Infotainment	Radio	V																																									
Cruze/Gasoline	Infotainment	Telematics communication interface control module	V																																									
Cruze/Diesel	Powertrain	Engine control module(2.0L LLW)	V	V		V																																						
Cruze/Diesel	Powertrain	Engine control module(2.0L LNP)	V	V	V		V																																					
Cruze/Diesel	Powertrain	Fuel pump control module	V																																									
Cruze/Diesel	Powertrain	Transmission control module	V																																									
Cruze/Diesel	Chassis	EBCM(Electronic brake control module)	V	V	V	V																																						
Cruze/Diesel	Chassis	Multi-Axis acceleration sensor module	V			V																																						
Cruze/Diesel	Chassis	Steering wheel angle sensor module	V			V																																						
Cruze/Diesel	Chassis	Electrinic power steering control module	V																																									
Cruze/Diesel	Body	Body control module	V	V	V	V																																						
Cruze/Diesel	Body	Immobilizer																																										
Cruze/Diesel	Body	SDM(Inflatable restraint sensing and diagnostic module)	V	V	V	V																																						
Cruze/Diesel	Body	Passenger presence module	V																																									
Cruze/Diesel	Body	Instrument panel cluster	V	V	V	V																																						
Cruze/Diesel	Body	Auto Heating ventilating and air conditioning	V	V	V	V																																						
Cruze/Diesel	Body	Manual Heating ventilating and air conditioning	V	V	V	V																																						
Cruze/Diesel	Body	Front seat heating control module	V	V	V	V																																						
Cruze/Diesel	Body	Park assist control module	V			V																																						
Cruze/Diesel	Body	Passive entry passive start	V																																									
Cruze/Diesel	Body	Steering column lock control module	V																																									
Cruze/Diesel	Infotainment	Radio	V																																									
Cruze/Diesel	Infotainment	Telematics communication interface control module	V																																									
Barina/Spark/Barina(T300)	Powertrain	Engine control module(1.4L LUJ)	V	V	V		V																																					
Barina/Spark/Barina(T300)	Powertrain	Engine control unit(1.6L LDE)	V	V	V	V																																						

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
Barina/Spark/Barina(T300)	Powertrain	TCM(Transmission control module)	V	V	V	V																																						
Barina/Spark/Barina(T300)	Chassis	Electronic brake control module	V	V		V																																						
Barina/Spark/Barina(T300)	Chassis	Multi-Axis acceleration sensor module	V			V																																						
Barina/Spark/Barina(T300)	Chassis	Steering wheel angle sensor module	V			V																																						
Barina/Spark/Barina(T300)	Body	Immobilizer																																										
Barina/Spark/Barina(T300)	Body	BCM(Body control module)	V	V	V		V																																					
Barina/Spark/Barina(T300)	Body	SDM(Inflatable restraintment sensing and diagnostic module)	V	V		V																																						
Barina/Spark/Barina(T300)	Body	IPC(Instrument Cluster)	V	V	V	V																																						
Barina/Spark/Barina(T300)	Information	Radio	V	V	V																																							
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LEB)	V	V	V	V																																						
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LMT)	V	V	V	V																																						
Barina/Spark/Barina Spark	Powertrain	Engine LPG	V																																									
Barina/Spark/Barina Spark	Powertrain	TCM(Transmission control module)	V	V	V	V																																						
Barina/Spark/Barina Spark	Chassis	Electronic brake control module	V	V		V																																						
Barina/Spark/Barina Spark	Chassis	Multi-Axis acceleration sensor module	V			V																																						
Barina/Spark/Barina Spark	Chassis	Electronic power steering control module	V	V		V																																						
Barina/Spark/Barina Spark	Chassis	Steering wheel angle sensor module	V			V																																						
Barina/Spark/Barina Spark	Body	SDM(Inflatable restraintment sensing and diagnostic module)	V	V	V	V																																						
Barina/Spark/Barina Spark	Body	IPC(Instrument Cluster)	V	V	V	V																																						
Barina/Spark/Barina Spark	Body	Keyless entry control module		V																																								
Barina/Spark/Barina Spark	Body	Passenger presensce module	V	V		V																																						
Barina/Spark/Barina(OPEL)	Engine	C 14 SE	V	V	V	V																																						
Barina/Spark/Barina(OPEL)	Engine	Z 14 XE	V	V	V	V																																						
Barina/Spark/Barina(OPEL)	Engine	Z 14 XEP	V	V	V	V																																						
Barina/Spark/Barina(OPEL)	Engine	Z 16 SE	V	V	V	V																																						
Barina/Spark/Barina(OPEL)	Engine	Z 18 XE	V	V	V	V																																						
Barina/Spark/Barina(OPEL)	Transmission	AF 13/14/20	V	V	V	V																																						
Barina/Spark/Barina(OPEL)	Transmission	AF 13II/20/22/30	V	V	V	V																																						
Barina/Spark/Barina(OPEL)	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																						
Barina/Spark/Barina(OPEL)	Chassis	ABS 5.3/5.4 +TC	V	V	V	V																																						
Barina/Spark/Barina(OPEL)	Chassis	ABS/ESP8	V	V	V	V																																						
Barina/Spark/Barina(OPEL)	Chassis	Electronic Power Steering	V	V		V																																						
Barina/Spark/Barina(OPEL)	Body	Immobiliser	V	V		V																																						
Barina/Spark/Barina(OPEL)	Body	Body Control Module	V	V	V	V																																						
Barina/Spark/Barina(OPEL)	Body	SRS Airbag	V	V		V																																						
Barina/Spark/Barina(OPEL)	Body	Instrument	V	V	V	V																																						
Barina/Spark/Barina(OPEL)	Information	Read security PIN code																																										
Barina/Spark/Barina(OPEL)	Information	Trip info display	V	V	V	V																																						

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.5 Sohc	V	V	V		V																																				
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.6 Dohc	V	V	V		V																																				
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	A/T Aisin5	V	V	V	V	V																																				
Barina/Spark/Barina(GM/DAEWOO)	Chassis	ABS	V	V	V		V																																				
Barina/Spark/Barina(GM/DAEWOO)	Body	Immobilizer																																									
Barina/Spark/Barina(GM/DAEWOO)	Body	Keyless entry																																									
Barina/Spark/Barina(GM/DAEWOO)	Body	Air Bag	V	V			V																																				
Volt		ECM(Engine control module)	V	V	V	V																																					
Volt		FPCM(Fuel pump control module)	V	V	V	V																																					
Volt		HVCM(Hybrid powertrain control module)	V	V	V	V																V																					
Volt		HVCM2(Hybrid powertrain control module 2)	V	V	V	V											V	V	V	V	V	V																					
Volt		TCM(Transmission control module)	V	V	V	V																																					
Volt		DMCM1(Driver motor control module 1)	V	V		V																																					
Volt		DMCM2(Driver motor control module 2)	V	V		V																																					
Volt		BCCM(Battery charger control module)	V	V		V																																					
Volt		BECM(Battery energy control module)	V	V		V																																					
Volt		ATFP(Auxiliary transmission fluid pump)	V	V		V																																					
Volt		EBCM(Electronic brake control module)	V	V	V	V																																				V	V
Volt		PBCM(Parking brake control module)	V	V	V	V																													V	V	V	V					
Volt		MAASM(Multi axis acceleration sensor module)	V			V																											V	V									
Volt		PSCM(Power steering control module)	V	V		V																																					
Volt		SWASM(Steering wheel angle sensor module)	V			V																	V	V																			
Volt		Immobilizer																														V											
Volt		BCM(Body control module)	V	V	V	V																							V														
Volt		SDM(Inflatable restraint sensing and diagnostic module)	V	V		V																																					
Volt		IC(Instrument cluster)	V	V		V																																					
Volt		Radio	V	V		V																																					
Volt		TCIC(Telematics communication interface control module)	V			V																																					
Volt		HVAC(Heating Ventilating and Air Conditioning)	V	V	V	V										V																											
Volt		CHCM(Coolant heater control module)	V			V																																					
Volt		SHCM(Seat heating control module)	V	V		V																																					
Volt		Keyless	V	V		V																																					
Volt		PACM(Parking assist control module)	V	V	V	V																				V																	
Volt		FVC(Front view camera)	V			V																																					
Volt		SCCM(Steering column lock control module)	V			V																																					
Captiva/Captiva	Powertrain	Engine Diesel	V	V	V		V																																				
Captiva/Captiva	Powertrain	Engine 2.4 Dohc	V	V	V		V																																				
Captiva/Captiva	Powertrain	Engine 3.2 Dohc	V	V	V																																						

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
Captiva/Captiva	Powertrain	Auto Transmission	V	V		V																																						
Captiva/Captiva	Chassis	EBCM(Electronic brake control module)	V	V	V		V																																					
Captiva/Captiva	Chassis	TCCM(Transfer case control module)	V	V	V																																							
Captiva/Captiva	Body	SDM(SRS Airbag)	V	V																																								
Captiva/Captiva	Body	IPC(Instrument panel cluster)	V	V	V		V																																					
Captiva/Captiva	Body	BCM(Body control module)	V	V	V		V																																					
Captiva/Captiva	Body	VTD(Theft deterrent module)	V	V																																								
Captiva/Captiva	Body	RFA(Remote function actuator)	V	V																																								
Captiva/Captiva 5/7	Powertrain	Engine control module(2.2L LNQ)	V	V	V		V																																					
Captiva/Captiva 5/7	Powertrain	Engine control module(2.4L LE5)	V	V	V		V																																					
Captiva/Captiva 5/7	Powertrain	Engine control module(3.0L LF1)	V	V	V		V																																					
Captiva/Captiva 5/7	Powertrain	Fuel pump control module	V																																									
Captiva/Captiva 5/7	Powertrain	Transmission control module	V	V	V	V																																						
Captiva/Captiva 5/7	Chassis	Electronic brake control module	V	V	V		V																																					
Captiva/Captiva 5/7	Chassis	Parking brake control module	V	V	V		V																																					
Captiva/Captiva 5/7	Chassis	Rear differential clutch control module	V	V	V		V																																					
Captiva/Captiva 5/7	Body	Body control module	V	V	V		V																																					
Captiva/Captiva 5/7	Body	Inflatable restraint sensing and diagnostic module	V	V		V																																						
Captiva/Captiva 5/7	Body	Instrument panel cluster	V	V			V																																					
Captiva/Captiva 5/7	Body	HVAC control module	V		V	V																																						
Captiva/Captiva 5/7	Body	Remote control door lock receiver	V	V	V	V																																						
Captiva/Captiva 5/7	Body	Theft deterrent module	V	V		V																																						
Captiva/Captiva 5/7	Body	Parking assist control module	V	V	V	V																																						
Captiva/Captiva 5/7	Infotainment	Radio	V																																									
VIVA		1.4/1.5 Dohc	V	V	V	V	V																																					
VIVA		1.6 Dohc	V	V	V	V	V																																					
VIVA		1.8 Dohc	V	V	V	V	V																																					
VIVA		A/T	V	V	V		V																																					
VIVA		ABS	V	V	V		V																																					
VIVA		SSPS	V	V	V		V																																					
VIVA		Immobilizer																																										
VIVA		Keyless entry																																										
VIVA		Air Bag	V	V			V																																					
Malibu		ECM 2.4L(Engine control module 2.4L LE9)	V	V	V	V																						V																
Malibu		ECM 2.0L(Engine control module 2.0L LBS)	V	V	V	V																																						
Malibu		TCM(Transmission control module)	V	V	V	V																																						
Malibu		EBCM(Electronic brake control module)	V	V	V	V					V	V	V	V	V																													
Malibu		MAASM(Multi axis acceleration sensor module)	V			V																												V	V									

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
Malibu		PSCM(Power steering control module)	V	V		V																																					
Malibu		SWASM(Steering wheel angle sensor module)	V			V																	V	V																			
Malibu		Immobilizer																														V											
Malibu		BCM(Body control module)	V	V	V	V																					V	V	V														
Malibu		SDM(Inflatable restraint sensing and diagnostic module)	V	V	V	V																																					
Malibu		IC(Instrument cluster)	V	V	V	V																																					
Malibu		Radio	V	V	V	V																																					
Malibu		HVAC(Heating Ventilating and Air Conditioning)	V	V	V	V										V																											
Malibu		Keyless	V	V	V	V																																					
Malibu		PACM(Parking assist control module)	V	V	V	V																				V																	
Malibu		SCCM(Steering column lock control module)	V	V		V																																					
Epica		2.0 Dohc(Beta)	V	V	V	V	V																																				
Epica		Engine Diesel	V	V	V		V																																				
Epica		A/T Aisin5(Beta)	V	V		V																																					
Epica		A/T GF 6	V	V		V																																					
Epica		ABS	V	V	V	V	V																																				
Epica		SSPS	V	V	V		V																																				
Epica		SDM(SRS AIRBAG)	V	V			V																																				
Epica		Keyless entry																																									
Epica		ISU/BCM	V	V	V		V																																				
Astra/Astra-F	Engine	C16SE	V	V	V	V																																					
Astra/Astra-F	Engine	C18SEL	V	V	V	V																																					
Astra/Astra-F	Transmission	AF 13/14/20	V	V	V	V																																					
Astra/Astra-F	Transmission	AF 13II/20/22/30	V	V	V	V																																					
Astra/Astra-F	Body	Immobilizer	V	V		V																																					
Astra/Astra-F	Body	Airbag-S	V	V		V																																					
Astra/Astra-G	Engine	Z 18 XE	V	V	V	V																																					
Astra/Astra-G	Engine	X 18 XE1	V	V	V	V																																					
Astra/Astra-G	Engine	Z 22 SE	V	V	V	V																																					
Astra/Astra-G	Transmission	AF 13-II/17/20/22	V	V	V	V																																					
Astra/Astra-G	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																					
Astra/Astra-G	Chassis	ABS 5.3/5.4 +TC	V	V	V	V																																					
Astra/Astra-G	Chassis	ESP	V	V		V																																					
Astra/Astra-G	Chassis	Electronic Power Steering	V	V	V	V																																					
Astra/Astra-G	Body	Immobiliser	V	V		V																																					
Astra/Astra-G	Body	SRS Airbag	V	V		V																																					
Astra/Astra-G	Body	Instrument	V	V	V	V																																					
Astra/Astra-G	Body	Engine Cooling Module	V	V	V	V																																					

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
Astra/Astra-G	Body	Add On Heater	V	V																																								
Astra/Astra-G	Body	Electronic Climate Control	V	V		V																																						
Astra/Astra-G	Body	Central Door Lock	V	V	V	V																																						
Astra/Astra-G	Body	Softtop Controller	V	V	V	V																																						
Astra/Astra-G	Information	Read security PIN code																																										
Astra/Astra-G	Infortainment System	Trip Info Display	V	V	V	V																																						
Astra/Astra-G	Infortainment System	Multi Info Display	V	V	V	V																																						
Astra/Astra-H	Engine	Z 18 XE	V	V	V	V																																						
Astra/Astra-H	Engine	Z 18 XER	V	V	V	V																																						
Astra/Astra-H	Engine	Z 19 DT(Beta)	V	V	V	V																																						
Astra/Astra-H	Engine	Z 20 LEH	V	V	V	V																																						
Astra/Astra-H	Engine	Z 20 LER	V	V	V	V																																						
Astra/Astra-H	Engine	Z 22 YH	V	V	V	V																																						
Astra/Astra-H	Transmission	AF 40-6(Beta)	V	V	V	V																																						
Astra/Astra-H	Transmission	AF 22-4	V	V	V	V																																						
Astra/Astra-H	Transmission	AF 17-4	V	V	V	V																																						
Astra/Astra-H	Chassis	ABS/TC/ESP	V			V																																						
Astra/Astra-H	Chassis	EHPS(Electrohydraulic power steering)	V	V	V	V																																						
Astra/Astra-H	Body	SDM(Airbag)	V	V		V																																						
Astra/Astra-H	Body	CIM(Steering column module)	V	V	V	V																																						
Astra/Astra-H	Body	IPC(Instrument control unit)	V	V	V	V																																						
Astra/Astra-H	Body	UEC(Underhood electrical centre)	V			V																																						
Astra/Astra-H	Body	REC(Rear electrical centre)	V	V	V	V																																						
Astra/Astra-H	Body	PAS(Park pilot)	V	V		V																																						
Astra/Astra-H	Body	SAC(Air conditioning)	V	V	V	V																																						
Astra/Astra-H	Body	Electrohydraulic hard top	V	V	V	V																																						
Combo/Corsa-B	Engine	C 14 SE	V	V	V	V																																						
Combo/Corsa-B	Engine	Z 14 XE	V	V	V	V																																						
Combo/Corsa-B	Engine	Z 14 XEP	V	V	V	V																																						
Combo/Corsa-B	Engine	Z 16 SE	V	V	V	V																																						
Combo/Corsa-B	Engine	Z 18 XE	V	V	V	V																																						
Combo/Corsa-B	Transmission	AF 13/14/20	V	V	V	V																																						
Combo/Corsa-B	Transmission	AF 13II/20/22/30	V	V	V	V																																						
Combo/Corsa-B	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																						
Combo/Corsa-B	Chassis	ABS 5.3/5.4 +TC	V	V	V	V																																						
Combo/Corsa-B	Chassis	ABS/ESP8	V	V	V	V																																						
Combo/Corsa-B	Chassis	Electronic Power Steering	V	V		V																																						
Combo/Corsa-B	Body	Immobiliser	V	V		V																																						

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
Combo/Corsa-B	Body	Body Control Module	V	V	V	V																																					
Combo/Corsa-B	Body	SRS Airbag	V	V		V																																					
Combo/Corsa-B	Body	Instrument	V	V	V	V																																					
Combo/Corsa-B	Information	Trip info display	V	V	V	V																																					
Combo/Corsa-C	Engine	Z 14 XE	V	V	V	V																																					
Combo/Corsa-C	Engine	Z 14 XEP	V	V	V	V																																					
Combo/Corsa-C	Engine	Z 16 SE	V	V	V	V																																					
Combo/Corsa-C	Engine	Z 18 XE	V	V	V	V																																					
Combo/Corsa-C	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																					
Combo/Corsa-C	Chassis	ABS 5.3/5.4 +TC	V	V	V	V																																					
Combo/Corsa-C	Chassis	Electronic Power Steering	V	V		V																																					
Combo/Corsa-C	Body	Immobiliser	V	V		V																																					
Combo/Corsa-C	Body	Body Control Module	V	V	V	V																																					
Combo/Corsa-C	Body	SRS Airbag	V	V		V																																					
Combo/Corsa-C	Body	Instrument	V	V	V	V																																					
Combo/Corsa-C	Information	Read security PIN code																																									
Trax		Engine Control Module 1.4L - 2WD	V	V	V	V																						V															
Trax		Engine Control Module 1.4L - AWD	V	V	V	V																						V															
Trax		Engine Control Module 1.8L - 2WD	V	V	V	V																						V															
Trax		Engine Control Module 1.8L - AWD	V	V	V	V																						V															
Trax		Engine Control Module 1.7L	V	V	V	V																						V															
Trax		Transmission	V	V	V	V																																					
Trax		Rear Differential Clutch Control Module - Beta	V	V	V	V			V	V																																	
Trax		EBCM(Electronic brake control module)	V	V	V	V					V	V	V	V	V																												
Trax		PSCM(Power steering control module)	V	V		V																																					
Trax		SWASM(Steering wheel angle sensor module)	V			V																											V	V									
Trax		Immobilizer																														V											
Trax		BCM(Body control module)	V	V	V	V																					V	V	V														
Trax		SDM(Inflatable restraint sensing and diagnostic module)	V	V		V																																					
Trax		IC(Instrument cluster)	V	V	V	V																				V																	
Trax		Radio	V	V	V	V																																					
Trax		HVAC(Heating Ventilating and Air Conditioning)	V	V	V	V																																					
Trax		SHCM(Seat heating control module)	V	V	V	V																																					
Trax		PACM(Parking assist control module)	V	V	V	V																				V																	
Jackaroo/Monterey	Engine	6VD1	V	V	V																																						
Jackaroo/Monterey	Engine	3.0 L4 4JX1	V	V	V	V																																					
Jackaroo/Monterey	Engine	3.2 V6 6VD1 Hitachi	V	V	V	V																																					
Jackaroo/Monterey	Engine	3.5 V6 6VE1 Hitachi	V	V	V	V																																					

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
Jackaroo/Monterey	Transmission	4L30E	V	V	V	V																																						
Jackaroo/Monterey	Transmission	AW30-40LE	V	V	V	V																																						
Jackaroo/Monterey	Body	Immobilizer	V	V		V																																						
Jackaroo/Monterey	Body	Airbag	V	V		V																																						
Jackaroo/Monterey	Body	Aniti theft warning	V		V	V																																						
Rodeo/Colorado/Rodeo	Engine	6VD1	V	V	V																																							
Rodeo/Colorado/Rodeo	Engine	2.2 L4 SOHC	V	V		V																																						
Rodeo/Colorado/Rodeo	Engine	2.X L4 HV240	V	V	V	V																																						
Rodeo/Colorado/Rodeo	Engine	3.2 V6 6VD1 Hitachi	V	V	V	V																																						
Rodeo/Colorado/Rodeo	Transmission	4L30E	V	V	V	V																																						
Rodeo/Colorado/Rodeo	Transmission	AW30-40LE	V	V	V	V																																						
Rodeo/Colorado/Rodeo	Body	Immobilizer	V	V		V																																						
Rodeo/Colorado/Rodeo	Body	Aniti theft warning	V		V	V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.2 L4 SOHC	V	V		V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.4 LP1 EURO3	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.X L4 HV240	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.0 iTD(4JH1-TC)	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.5 V6 6VE1 Hitachi	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	V6 Engine	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AT JR405E	V	V		V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AW30-40LE	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	Auto transmission	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Chassis	ABS	V		V	V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Immobilizer	V	V		V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	PIM(Powertrain interface module)	V			V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	SRS airbag	V	V		V																																						
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Aniti theft warning	V		V	V																																						
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	2.4 LP1 EURO3	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Delphi)	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Transtron)	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	V6 Engine	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Chassis	ABS	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	AW30-40LE	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	Auto transmission	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Immobilizer(V6 Engine)	V	V		V																																						
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	SRS(Airbag)	V	V	V	V																																						
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Aniti theft warning	V		V	V																																						
New Colorado/Colorado7	Engine	2.8L Diesel(LWH)	V	V	V	V																																						

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU4	V	V	V	V																																						
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU5	V	V	V	V																																						
New Colorado/Colorado7	Chassis	Electronic brake control module	V	V	V	V																																						
New Colorado/Colorado7	Chassis	Transfer case control module	V	V	V	V																																						
New Colorado/Colorado7	Chassis	Steering wheel angle sensor module	V			V																																						
New Colorado/Colorado7	Chassis	Multi-Axis acceleration sensor module	V			V																																						
New Colorado/Colorado7	Transmission	Auto transmission(6SP)	V	V	V	V																																						
New Colorado/Colorado7	Body	Immobilizer(New Colorado)																																										
New Colorado/Colorado7	Body	Body Control Module	V	V	V	V																																						
New Colorado/Colorado7	Body	Instrument cluster	V	V	V	V																																						
New Colorado/Colorado7	Body	SRS(Airbag)	V	V	V	V																																						
Tigra/Tigra-B	Engine	C 14 SE	V	V	V	V																																						
Tigra/Tigra-B	Engine	Z 14 XE	V	V	V	V																																						
Tigra/Tigra-B	Engine	Z 14 XEP	V	V	V	V																																						
Tigra/Tigra-B	Engine	Z 16 SE	V	V	V	V																																						
Tigra/Tigra-B	Engine	Z 18 XE	V	V	V	V																																						
Tigra/Tigra-B	Transmission	AF 13/14/20	V	V	V	V																																						
Tigra/Tigra-B	Transmission	AF 13II/20/22/30	V	V	V	V																																						
Tigra/Tigra-B	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																						
Tigra/Tigra-B	Chassis	ABS 5.3/5.4 +TC	V	V	V	V																																						
Tigra/Tigra-B	Chassis	ABS/ESP8	V	V	V	V																																						
Tigra/Tigra-B	Chassis	Electronic Power Steering	V	V		V																																						
Tigra/Tigra-B	Body	Immobiliser	V	V		V																																						
Tigra/Tigra-B	Body	Body Control Module	V	V	V	V																																						
Tigra/Tigra-B	Body	SRS Airbag	V	V		V																																						
Tigra/Tigra-B	Body	Instrument	V	V	V	V																																						
Tigra/Tigra-B	Information	Read security PIN code																																										
Tigra/Tigra-B	Information	Trip info display	V	V	V	V																																						
Vectra/Vectra-B	Engine	C 20 SEL	V	V	V	V																																						
Vectra/Vectra-B	Engine	C 22 SEL	V	V	V	V																																						
Vectra/Vectra-B	Engine	Z 22 SE	V	V		V																																						
Vectra/Vectra-B	Engine	X 25 XE	V	V	V	V																																						
Vectra/Vectra-B	Engine	Y 26 SE	V	V	V																																							
Vectra/Vectra-B	Transmission	AF 13/14/20	V	V	V	V																																						
Vectra/Vectra-B	Transmission	AF 13II/20/22/30	V	V	V	V																																						
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22	V	V	V	V																																						
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																						
Vectra/Vectra-B	Chassis	ABS 5.3/5.4 +TC	V	V	V	V																																						

Model	Group	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	System Identification	System Information	AWD Disabled by Malfunction Counter Reset	Rear Drive Clutch Service Calibration Setup	ABS Left Front Solenoid Valves	ABS Right Front Solenoid Valves	ABS Left Rear Solenoid Valves	ABS Right Rear Solenoid Valves	Automated Brake Bleed	HVAC After blow Configuration	Hybrid/EV Battery pack coolant solenoid valve learn	Hybrid/EV Battery pack capacity learn	Passenger compartment heater coolant control solenoid valve learn	Fuel economy reset	Hybrid/EV Battery pack data reset	Clear secured high voltage DTCs	Yaw Rate Sensor Reset	Yaw Rate Sensor Learn	Info Display/Infotainment faceplate reset	CAN Bus configuration learning	Read LIN Bus Device ID Information	Brake pedal position sensor learn	Clear driver window learned values	Clear passenger window learned values	Tire pressure sensors learn	Tire Type/Pressure selection	Key programming	Steering wheel angle sensor reset	Steering wheel angle sensor learn	Park brake cable replacement	Park brake cable service apply	Park brake cable service release	Park brake calibration	Brake pressure sensor calibration	Steering wheel angle sensor learn	Brake control offset learn	Electronic brake control module learn
Vectra/Vectra-B	Body	Immobiliser	V	V		V																																						
Vectra/Vectra-B	Body	SRS Airbag SAB6	V	V		V																																						
Vectra/Vectra-B	Body	Central Door Lock	V	V	V	V																																						
Vectra/Vectra-B	Body	Instrument	V	V		V																																						
Vectra/Vectra-B	Information	Read security PIN code																																										
Vectra/Vectra-B	Infotainment System	Trip info display	V	V	V	V																																						
Vectra/Vectra-C	Engine	Z 32 SE	V	V	V	V																																						
Vectra/Vectra-C	Transmission	AF 23-5/33-5/40-6	V	V	V	V																																						
Vectra/Vectra-C	Chassis	ABS/TC/ESP	V			V																																						
Vectra/Vectra-C	Chassis	EHPS(Electrohydraulic power steering)	V	V		V																																						
Vectra/Vectra-C	Body	SDM(Airbag)	V	V		V																																						
Vectra/Vectra-C	Body	CIM(Steering column module)	V	V	V	V																																						
Vectra/Vectra-C	Body	BCM(Body control module)	V		V	V																																						
Vectra/Vectra-C	Body	IPC(Instrument control unit)	V		V	V																																						
Vectra/Vectra-C	Body	REC(Rear electrical control)	V			V																																						
Vectra/Vectra-C	Body	UEC(Underhood electrical control)	V		V	V																																						
Vectra/Vectra-C	Body	DDM(Driver door module)	V		V	V																																						
Vectra/Vectra-C	Body	PDM(Passenger door module)	V		V	V																																						
Vectra/Vectra-C	Body	SLM(Shift lever module)	V			V																																						
Vectra/Vectra-C	Body	Electronic seat	V		V	V																																						
Vectra/Vectra-C	Information	Read security PIN code																																										
Zafira/2001-2005	Engine	Z 22 SE	V	V	V	V																																						
Zafira/2001-2005	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																						
Zafira/2001-2005	Chassis	ABS 5.3/5.4 +TC	V	V	V	V																																						
Zafira/2001-2005	Chassis	Electronic Power Steering	V	V	V	V																																						
Zafira/2001-2005	Body	Immobiliser	V	V		V																																						
Zafira/2001-2005	Body	SRS Airbag	V	V		V																																						
Zafira/2001-2005	Body	Instrument	V	V	V	V																																						
Zafira/2001-2005	Body	Engine Cooling Module	V	V		V																																						
Zafira/2001-2005	Body	Central Door Lock	V	V	V	V																																						
Zafira/2001-2005	Information	Read security PIN code																																										
Zafira/2001-2005	Infortainment System	Trip Info Display	V	V	V	V																																						

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
Commodore/VR	Engine	V6/V8																																										
Commodore/VR	Transmission	A/T																																										
Commodore/VR	Chassis	ABS																																										
Commodore/VR	Body	SRS Airbag																																										
Commodore/VR	Body	BCM(Body control module)																																										
Commodore/VR	Body	TDM																																										
Commodore/VS	Engine	V6																																										
Commodore/VS	Engine	V8																																										
Commodore/VS	Transmission	V6 A/T																																										
Commodore/VS	Transmission	V8 A/T																																										
Commodore/VS	Chassis	ABS																																										
Commodore/VS	Body	SRS Airbag																																										
Commodore/VS	Body	BCM(Body control module)																																	V									
Commodore/VT(Include VSv8)	Engine	V6																																										
Commodore/VT(Include VSv8)	Engine	V8																																										
Commodore/VT(Include VSv8)	Engine	V8 GEN III																																										
Commodore/VT(Include VSv8)	Transmission	A/T																																										
Commodore/VT(Include VSv8)	Transmission	A/T GEN III																																										
Commodore/VT(Include VSv8)	Chassis	ABS																																										
Commodore/VT(Include VSv8)	Body	SRS Airbag																																										
Commodore/VT(Include VSv8)	Body	BCM(Body control module)																																	V	V	V							
Commodore/VT(Include VSv8)	Body	Instrument																																										
Commodore/VT(Include VSv8)	Body	PIM(Powertrain Interface Module)																														V												
Commodore/VT(Include VSv8)	Body	Climate Control																																										
Commodore/VX	Engine	V6																																										
Commodore/VX	Engine	V6 Supercharged																																										
Commodore/VX	Engine	V8 GEN III																																										
Commodore/VX	Transmission	A/T																																										
Commodore/VX	Transmission	A/T GEN III																																										
Commodore/VX	Chassis	ABS																																										
Commodore/VX	Body	SRS Airbag																																										
Commodore/VX	Body	BCM(Body control module)																																	V	V	V							
Commodore/VX	Body	Instrument																																										
Commodore/VX	Body	PIM(Powertrain Interface Module)																														V												
Commodore/VX	Body	Climate Control																																										
Commodore/VY	Engine	V6																																										
Commodore/VY	Engine	V6 Supercharged																																										
Commodore/VY	Engine	V8 GEN III																																										

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
Commodore/VY	Transmission	A/T																																										
Commodore/VY	Transmission	A/T GEN III																																										
Commodore/VY	Chassis	ABS																																										
Commodore/VY	Body	SRS Airbag																																										
Commodore/VY	Body	BCM(Body control module)																																			V						
Commodore/VY	Body	Instrument																																										
Commodore/VY	Body	PIM(Powertrain Interface Module)																														V								V				
Commodore/VY	Body	Audio System																																										
Commodore/VZ	Engine	V6																																										
Commodore/VZ	Engine	V6 Supercharged																																										
Commodore/VZ	Engine	V8 GEN III																																										
Commodore/VZ	Engine	V8 GEN IV																																										
Commodore/VZ	Transmission	A/T																																										
Commodore/VZ	Transmission	A/T GEN III																																										
Commodore/VZ	Chassis	ABS/TC/ESP8.0																																						V				
Commodore/VZ	Chassis	ABS/ETC																																										
Commodore/VZ	Body	SRS Airbag																																										
Commodore/VZ	Body	BCM(Body control module)																			V																							
Commodore/VZ	Body	PIM(Powertrain Interface Module)																														V	V							V	V			
Commodore/VZ	Body	Instrument																																										
Commodore/VZ	Body	Audio System																																										
Commodore/VE	Engine	V6																																										
Commodore/VE	Engine	V8 GEN IV																																										
Commodore/VE	Transmission	A/T																																										
Commodore/VE	Chassis	EBCM(Electronic brake control module)																																										
Commodore/VE	Chassis	TPMS(Tyre pressure monitor system)																																										
Commodore/VE	Chassis	Fuel Pump Control																																										
Commodore/VE	Body	BCM(Body control module)																																										
Commodore/VE	Body	VTM(Theft deterrent module)																																										
Commodore/VE	Body	RFA(Remote function actuator)																																										
Commodore/VE	Body	SDM(SRS Airbag)																																										
Commodore/VE	Body	IPC(Instrument Panel Cluster)																																V	V									
Commodore/VE	Body	HVAC(Heating Ventilating and Air Conditioning)																																										
Commodore/VE	Body	MSM																																										
Commodore/VE	Body	Parking Assist																																										
Commodore/VE	Body	AHL																																										
Commodore/VE	Infotainment System	Audio System																													V													
Commodore/VE	Infotainment System	Rear Seat Entertainment																																										

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
VF Comodore	Powertrain	3.0L LFW(Beta)					V		V	V	V	V	V																															
VF Comodore	Powertrain	3.6L LFX			V		V		V	V	V	V	V																															
VF Comodore	Powertrain	6.2L LS3(Beta)			V		V		V	V	V	V	V																															
VF Comodore	Powertrain	FICM(Fuel injector control module)																																										
VF Comodore	Powertrain	TCM(Transmission control unit)		V																																								
VF Comodore	Chassis	CCM(Chassis control module)											V																															
VF Comodore	Chassis	EBCM(Electronic brake control module)	V																																									
VF Comodore	Chassis	PBCM(Parking brake control module)																																										
VF Comodore	Chassis	PSCM(Power steering control module)																																										
VF Comodore	Chassis	SWASM(Steering wheel angle sensor module)																																										
VF Comodore	Chassis	SCM(Suspension control module)																																										
VF Comodore	Body	Immobilizer																																										
VF Comodore	Body	BCM(Body control module)																																										
VF Comodore	Body	SDM(Inflatable restraint sensing and diagnostic module)																																										
VF Comodore	Body	IC(Instrument cluster)																																										
VF Comodore	Body	HDM(Head-up display module)																																										
VF Comodore	Body	RCP(Radio control panel)																																										
VF Comodore	Body	HVACCP(Heating Ventilating and Air Conditioning control panel)																																										
VF Comodore	Body	Radio																																										
VF Comodore	Body	HVAC(Heating Ventilating and Air Conditioning)																																										
VF Comodore	Body	RODCM(Right side object detection control module)																																										
VF Comodore	Body	LODCM(Left side object detection control module)																																										
VF Comodore	Body	Keyless																																										
VF Comodore	Body	PACM(Parking assist control module)																																										
VF Comodore	Body	FVCM(Front view camera module)																																										
VF Comodore	Body	SCCM(Steering column lock control module)																																										
YG Cruze		Engine																																										
YG Cruze		Transmission																																										
YG Cruze		ABS																																										
YG Cruze		EPS																																										
YG Cruze		Immobilizer																																										
YG Cruze		Airbag																																										
Cruze/Gasoline	Powertrain	Engine control module(1.4L LUJ)																																										
Cruze/Gasoline	Powertrain	Engine control module(1.8L 2H0)																																										
Cruze/Gasoline	Powertrain	Fuel pump control module																																										
Cruze/Gasoline	Powertrain	Transmission control module																																										
Cruze/Gasoline	Chassis	EBCM(Electronic brake control module)																																										
Cruze/Gasoline	Chassis	Multi-Axis acceleration sensor module																																										

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
Cruze/Gasoline	Chassis	Steering wheel angle sensor module																																										
Cruze/Gasoline	Chassis	Electrinic power steering control module																				V	V																					
Cruze/Gasoline	Body	Body control module																																										
Cruze/Gasoline	Body	Immobilizer																																										
Cruze/Gasoline	Body	SDM(Inflatable restraint sensing and diagnostic module)																																										
Cruze/Gasoline	Body	Passenger presence module																																										
Cruze/Gasoline	Body	Instrument panel cluster																																										
Cruze/Gasoline	Body	Auto Heating ventilating and air conditioning																																										
Cruze/Gasoline	Body	Manual Heating ventilating and air conditioning																																										
Cruze/Gasoline	Body	Front seat heating control module																																										
Cruze/Gasoline	Body	Park assist control module																																										
Cruze/Gasoline	Body	Passive entry passive start																																										
Cruze/Gasoline	Body	Steering column lock control module																																										
Cruze/Gasoline	Infotainment	Radio																																										
Cruze/Gasoline	Infotainment	Telematics communication interface control module																																										
Cruze/Diesel	Powertrain	Engine control module(2.0L LLW)																																										
Cruze/Diesel	Powertrain	Engine control module(2.0L LNP)																																										
Cruze/Diesel	Powertrain	Fuel pump control module																																										
Cruze/Diesel	Powertrain	Transmission control module																																										
Cruze/Diesel	Chassis	EBCM(Electronic brake control module)																																										
Cruze/Diesel	Chassis	Multi-Axis acceleration sensor module																																										
Cruze/Diesel	Chassis	Steering wheel angle sensor module																																										
Cruze/Diesel	Chassis	Electrinic power steering control module																																										
Cruze/Diesel	Body	Body control module																																										
Cruze/Diesel	Body	Immobilizer																																										
Cruze/Diesel	Body	SDM(Inflatable restraint sensing and diagnostic module)																																										
Cruze/Diesel	Body	Passenger presence module																																										
Cruze/Diesel	Body	Instrument panel cluster																																										
Cruze/Diesel	Body	Auto Heating ventilating and air conditioning																																										
Cruze/Diesel	Body	Manual Heating ventilating and air conditioning																																										
Cruze/Diesel	Body	Front seat heating control module																																										
Cruze/Diesel	Body	Park assist control module																																										
Cruze/Diesel	Body	Passive entry passive start																																										
Cruze/Diesel	Body	Steering column lock control module																																										
Cruze/Diesel	Infotainment	Radio																																										
Cruze/Diesel	Infotainment	Telematics communication interface control module																																										
Barina/Spark/Barina(T300)	Powertrain	Engine control module(1.4L LUJ)																																										
Barina/Spark/Barina(T300)	Powertrain	Engine control unit(1.6L LDE)																																										

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
Barina/Spark/Barina(T300)	Powertrain	TCM(Transmission control module)																																										
Barina/Spark/Barina(T300)	Chassis	Electronic brake control module																																										
Barina/Spark/Barina(T300)	Chassis	Multi-Axis acceleration sensor module																																										
Barina/Spark/Barina(T300)	Chassis	Steering wheel angle sensor module																																										
Barina/Spark/Barina(T300)	Body	Immobilizer																									V																	
Barina/Spark/Barina(T300)	Body	BCM(Body control module)																																										
Barina/Spark/Barina(T300)	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																										
Barina/Spark/Barina(T300)	Body	IPC(Instrument Cluster)																																										
Barina/Spark/Barina(T300)	Information	Radio																																										
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LEB)																																										
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LMT)																																										
Barina/Spark/Barina Spark	Powertrain	Engine LPG																																										
Barina/Spark/Barina Spark	Powertrain	TCM(Transmission control module)																																										
Barina/Spark/Barina Spark	Chassis	Electronic brake control module																																										
Barina/Spark/Barina Spark	Chassis	Multi-Axis acceleration sensor module																																										
Barina/Spark/Barina Spark	Chassis	Electronic power steering control module																																										
Barina/Spark/Barina Spark	Chassis	Steering wheel angle sensor module																																										
Barina/Spark/Barina Spark	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																										
Barina/Spark/Barina Spark	Body	IPC(Instrument Cluster)																																										
Barina/Spark/Barina Spark	Body	Keyless entry control module																								V																		
Barina/Spark/Barina Spark	Body	Passenger presensce module																																										
Barina/Spark/Barina(OPEL)	Engine	C 14 SE																																										
Barina/Spark/Barina(OPEL)	Engine	Z 14 XE																																										
Barina/Spark/Barina(OPEL)	Engine	Z 14 XEP																																				V						
Barina/Spark/Barina(OPEL)	Engine	Z 16 SE																																										
Barina/Spark/Barina(OPEL)	Engine	Z 18 XE																																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13/14/20																																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13II/20/22/30																																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13-II/17/20/22 CAN																																										
Barina/Spark/Barina(OPEL)	Chassis	ABS 5.3/5.4 +TC																																										
Barina/Spark/Barina(OPEL)	Chassis	ABS/ESP8																																										
Barina/Spark/Barina(OPEL)	Chassis	Electronic Power Steering																																										
Barina/Spark/Barina(OPEL)	Body	Immobiliser																																										
Barina/Spark/Barina(OPEL)	Body	Body Control Module													V																													
Barina/Spark/Barina(OPEL)	Body	SRS Airbag																																										
Barina/Spark/Barina(OPEL)	Body	Instrument														V																												
Barina/Spark/Barina(OPEL)	Information	Read security PIN code															V																											
Barina/Spark/Barina(OPEL)	Information	Trip info display																																										

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.5 Sohc																																									
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.6 Dohc																																									
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	A/T Aisin5																																									
Barina/Spark/Barina(GM/DAEWOO)	Chassis	ABS																																									
Barina/Spark/Barina(GM/DAEWOO)	Body	Immobilizer																										V	V	V													
Barina/Spark/Barina(GM/DAEWOO)	Body	Keyless entry																							V	V	V																
Barina/Spark/Barina(GM/DAEWOO)	Body	Air Bag																																									
Volt		ECM(Engine control module)						V	V	V	V	V					V																										
Volt		FPCM(Fuel pump control module)										V																															
Volt		HVCM(Hybrid powertrain control module)																																									
Volt		HVCM2(Hybrid powertrain control module 2)																																									
Volt		TCM(Transmission control module)		V																																							
Volt		DMCM1(Driver motor control module 1)																																									
Volt		DMCM2(Driver motor control module 2)																																									
Volt		BCCM(Battery charger control module)																																									
Volt		BECM(Battery energy control module)																																									
Volt		ATFP(Auxiliary transmission fluid pump)																																									
Volt		EBCM(Electronic brake control module)	V																																								
Volt		PBCM(Parking brake control module)																																									
Volt		MAASM(Multi axis acceleration sensor module)																																									
Volt		PSCM(Power steering control module)																																									
Volt		SWASM(Steering wheel angle sensor module)																																									
Volt		Immobilizer																																									
Volt		BCM(Body control module)																V																									
Volt		SDM(Inflatable restraint sensing and diagnostic module)																																									
Volt		IC(Instrument cluster)																																									
Volt		Radio																																									
Volt		TCIC(Telematics communication interface control module)																																									
Volt		HVAC(Heating Ventilating and Air Conditioning)																																									
Volt		CHCM(Coolant heater control module)																																									
Volt		SHCM(Seat heating control module)																																									
Volt		Keyless																																									
Volt		PACM(Parking assist control module)																																									
Volt		FVC(Front view camera)																																									
Volt		SCCM(Steering column lock control module)																																									
Captiva/Captiva	Powertrain	Engine Diesel																																									
Captiva/Captiva	Powertrain	Engine 2.4 Dohc																																									
Captiva/Captiva	Powertrain	Engine 3.2 Dohc																																									

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
Captiva/Captiva	Powertrain	Auto Transmission																																										
Captiva/Captiva	Chassis	EBCM(Electronic brake control module)																																										
Captiva/Captiva	Chassis	TCCM(Transfer case control module)																																										
Captiva/Captiva	Body	SDM(SRS Airbag)																																										
Captiva/Captiva	Body	IPC(Instrument panel cluster)																																										
Captiva/Captiva	Body	BCM(Body control module)																																										
Captiva/Captiva	Body	VTD(Theft deterrent module)																																										
Captiva/Captiva	Body	RFA(Remote function actuator)																																										
Captiva/Captiva 5/7	Powertrain	Engine control module(2.2L LNQ)																																										
Captiva/Captiva 5/7	Powertrain	Engine control module(2.4L LE5)																																										
Captiva/Captiva 5/7	Powertrain	Engine control module(3.0L LF1)																																										
Captiva/Captiva 5/7	Powertrain	Fuel pump control module																																										
Captiva/Captiva 5/7	Powertrain	Transmission control module																																										
Captiva/Captiva 5/7	Chassis	Electronic brake control module																																										
Captiva/Captiva 5/7	Chassis	Parking brake control module																																										
Captiva/Captiva 5/7	Chassis	Rear differential clutch control module																																										
Captiva/Captiva 5/7	Body	Body control module																																										
Captiva/Captiva 5/7	Body	Inflatable restraint sensing and diagnostic module																																										
Captiva/Captiva 5/7	Body	Instrument panel cluster																																										
Captiva/Captiva 5/7	Body	HVAC control module																																										
Captiva/Captiva 5/7	Body	Remote control door lock receiver																																										
Captiva/Captiva 5/7	Body	Theft deterrent module																																										
Captiva/Captiva 5/7	Body	Parking assist control module																																										
Captiva/Captiva 5/7	Infotainment	Radio																																										
VIVA		1.4/1.5 Dohc																																										
VIVA		1.6 Dohc																																										
VIVA		1.8 Dohc																																										
VIVA		A/T																																										
VIVA		ABS																																										
VIVA		SSPS																																										
VIVA		Immobilizer																										V	V	V														
VIVA		Keyless entry																							V	V	V																	
VIVA		Air Bag																																										
Malibu		ECM 2.4L(Engine control module 2.4L LE9)						V	V	V	V	V	V	V																														
Malibu		ECM 2.0L(Engine control module 2.0L LBS)				V			V																																			
Malibu		TCM(Transmission control module)																																										
Malibu		EBCM(Electronic brake control module)																																										
Malibu		MAASM(Multi axis acceleration sensor module)																																										

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
Malibu		PSCM(Power steering control module)																				V	V	V																				
Malibu		SWASM(Steering wheel angle sensor module)																																										
Malibu		Immobilizer																																										
Malibu		BCM(Body control module)																																										
Malibu		SDM(Inflatable restraint sensing and diagnostic module)																																										
Malibu		IC(Instrument cluster)																																										
Malibu		Radio																																										
Malibu		HVAC(Heating Ventilating and Air Conditioning)																																										
Malibu		Keyless																																										
Malibu		PACM(Parking assist control module)																																										
Malibu		SCCM(Steering column lock control module)																																										
Epica		2.0 Dohc(Beta)																																										
Epica		Engine Diesel																																										
Epica		A/T Aisin5(Beta)																																										
Epica		A/T GF 6																																										
Epica		ABS																																										
Epica		SSPS																																										
Epica		SDM(SRS AIRBAG)																																										
Epica		Keyless entry																							V	V	V																	
Epica		ISU/BCM																																										
Astra/Astra-F	Engine	C16SE																																										
Astra/Astra-F	Engine	C18SEL																																										
Astra/Astra-F	Transmission	AF 13/14/20																																										
Astra/Astra-F	Transmission	AF 13II/20/22/30																																										
Astra/Astra-F	Body	Immobilizer																																										
Astra/Astra-F	Body	Airbag-S																																										
Astra/Astra-G	Engine	Z 18 XE																																										
Astra/Astra-G	Engine	X 18 XE1																																										
Astra/Astra-G	Engine	Z 22 SE																																				V						
Astra/Astra-G	Transmission	AF 13-II/17/20/22																																										
Astra/Astra-G	Transmission	AF 13-II/17/20/22 CAN																																										
Astra/Astra-G	Chassis	ABS 5.3/5.4 +TC																																										
Astra/Astra-G	Chassis	ESP																																										
Astra/Astra-G	Chassis	Electronic Power Steering																																										
Astra/Astra-G	Body	Immobiliser																																										
Astra/Astra-G	Body	SRS Airbag																																										
Astra/Astra-G	Body	Instrument																																										
Astra/Astra-G	Body	Engine Cooling Module																																										

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
Astra/Astra-G	Body	Add On Heater																																										
Astra/Astra-G	Body	Electronic Climate Control																																										
Astra/Astra-G	Body	Central Door Lock																																										
Astra/Astra-G	Body	Softtop Controller																																										
Astra/Astra-G	Information	Read security PIN code															V																											
Astra/Astra-G	Infortainment System	Trip Info Display																																										
Astra/Astra-G	Infortainment System	Multi Info Display																																										
Astra/Astra-H	Engine	Z 18 XE																																										
Astra/Astra-H	Engine	Z 18 XER																																										
Astra/Astra-H	Engine	Z 19 DT(Beta)																																										
Astra/Astra-H	Engine	Z 20 LEH																																				V						
Astra/Astra-H	Engine	Z 20 LER																																				V						
Astra/Astra-H	Engine	Z 22 YH																																										
Astra/Astra-H	Transmission	AF 40-6(Beta)																																										
Astra/Astra-H	Transmission	AF 22-4																													V													
Astra/Astra-H	Transmission	AF 17-4																													V													
Astra/Astra-H	Chassis	ABS/TC/ESP																																										
Astra/Astra-H	Chassis	EHPS(Electrohydraulic power steering)																																										
Astra/Astra-H	Body	SDM(Airbag)																																										
Astra/Astra-H	Body	CIM(Steering column module)																																										
Astra/Astra-H	Body	IPC(Instrument control unit)																																										
Astra/Astra-H	Body	UEC(Underhood electrical centre)																																										
Astra/Astra-H	Body	REC(Rear electrical centre)																																										
Astra/Astra-H	Body	PAS(Park pilot)																																										
Astra/Astra-H	Body	SAC(Air conditioning)																																										
Astra/Astra-H	Body	Electrohydraulic hard top																																										
Combo/Corsa-B	Engine	C 14 SE																																										
Combo/Corsa-B	Engine	Z 14 XE																																										
Combo/Corsa-B	Engine	Z 14 XEP																																				V						
Combo/Corsa-B	Engine	Z 16 SE																																										
Combo/Corsa-B	Engine	Z 18 XE																																										
Combo/Corsa-B	Transmission	AF 13/14/20																																										
Combo/Corsa-B	Transmission	AF 13II/20/22/30																																										
Combo/Corsa-B	Transmission	AF 13-II/17/20/22 CAN																																										
Combo/Corsa-B	Chassis	ABS 5.3/5.4 +TC																																										
Combo/Corsa-B	Chassis	ABS/ESP8																																										
Combo/Corsa-B	Chassis	Electronic Power Steering																																										
Combo/Corsa-B	Body	Immobiliser																																										

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
Combo/Corsa-B	Body	Body Control Module																																										
Combo/Corsa-B	Body	SRS Airbag																																										
Combo/Corsa-B	Body	Instrument																																										
Combo/Corsa-B	Information	Trip info display																																										
Combo/Corsa-C	Engine	Z 14 XE																																										
Combo/Corsa-C	Engine	Z 14 XEP																																				V						
Combo/Corsa-C	Engine	Z 16 SE																																										
Combo/Corsa-C	Engine	Z 18 XE																																										
Combo/Corsa-C	Transmission	AF 13-II/17/20/22 CAN																																										
Combo/Corsa-C	Chassis	ABS 5.3/5.4 +TC																																										
Combo/Corsa-C	Chassis	Electronic Power Steering																																										
Combo/Corsa-C	Body	Immobiliser																																										
Combo/Corsa-C	Body	Body Control Module																																										
Combo/Corsa-C	Body	SRS Airbag																																										
Combo/Corsa-C	Body	Instrument																																										
Combo/Corsa-C	Information	Read security PIN code															V																											
Trax		Engine Control Module 1.4L - 2WD							V	V	V	V	V	V																														
Trax		Engine Control Module 1.4L - AWD							V	V	V	V	V	V																														
Trax		Engine Control Module 1.8L - 2WD					V		V	V	V	V	V																														
Trax		Engine Control Module 1.8L - AWD							V	V	V	V	V	V																														
Trax		Engine Control Module 1.7L							V	V		V																																
Trax		Transmission																																										
Trax		Rear Differential Clutch Control Module - Beta																																										
Trax		EBCM(Electronic brake control module)																																										
Trax		PSCM(Power steering control module)																																										
Trax		SWASM(Steering wheel angle sensor module)																																										
Trax		Immobilizer																																										
Trax		BCM(Body control module)																																										
Trax		SDM(Inflatable restraint sensing and diagnostic module)																																										
Trax		IC(Instrument cluster)																																										
Trax		Radio																																										
Trax		HVAC(Heating Ventilating and Air Conditioning)																																										
Trax		SHCM(Seat heating control module)																																										
Trax		PACM(Parking assist control module)																																										
Jackaroo/Monterey	Engine	6VD1																																										
Jackaroo/Monterey	Engine	3.0 L4 4JX1																																										
Jackaroo/Monterey	Engine	3.2 V6 6VD1 Hitachi																																										
Jackaroo/Monterey	Engine	3.5 V6 6VE1 Hitachi																																										

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
Jackaroo/Monterey	Transmission	4L30E																																										
Jackaroo/Monterey	Transmission	AW30-40LE																																										
Jackaroo/Monterey	Body	Immobilizer																																										
Jackaroo/Monterey	Body	Airbag																																										
Jackaroo/Monterey	Body	Aniti theft warning																																										
Rodeo/Colorado/Rodeo	Engine	6VD1																																										
Rodeo/Colorado/Rodeo	Engine	2.2 L4 SOHC																																										
Rodeo/Colorado/Rodeo	Engine	2.X L4 HV240																																										
Rodeo/Colorado/Rodeo	Engine	3.2 V6 6VD1 Hitachi																																										
Rodeo/Colorado/Rodeo	Transmission	4L30E																																										
Rodeo/Colorado/Rodeo	Transmission	AW30-40LE																																										
Rodeo/Colorado/Rodeo	Body	Immobilizer																												V														
Rodeo/Colorado/Rodeo	Body	Aniti theft warning																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.2 L4 SOHC																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.4 LP1 EURO3																																					V	V				
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.X L4 HV240																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.0 iTD(4JH1-TC)																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.5 V6 6VE1 Hitachi																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	V6 Engine																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AT JR405E																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AW30-40LE																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	Auto transmission																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Chassis	ABS																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Immobilizer																												V														
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	PIM(Powertrain interface module)																																							V	V	V
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	SRS airbag																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Aniti theft warning																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	2.4 LP1 EURO3																																					V	V				
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Delphi)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Transtron)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	V6 Engine																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Chassis	ABS																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	AW30-40LE																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	Auto transmission																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Immobilizer(V6 Engine)																												V														
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	SRS(Airbag)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Aniti theft warning																																										
New Colorado/Colorado7	Engine	2.8L Diesel(LWH)																																										

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU4																																									
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU5																																									
New Colorado/Colorado7	Chassis	Electronic brake control module																																									
New Colorado/Colorado7	Chassis	Transfer case control module																	V																								
New Colorado/Colorado7	Chassis	Steering wheel angle sensor module																																									
New Colorado/Colorado7	Chassis	Multi-Axis acceleration sensor module																																									
New Colorado/Colorado7	Transmission	Auto transmission(6SP)																		V																							
New Colorado/Colorado7	Body	Immobilizer(New Colorado)																									V																
New Colorado/Colorado7	Body	Body Control Module																V																									
New Colorado/Colorado7	Body	Instrument cluster																																									
New Colorado/Colorado7	Body	SRS(Airbag)																																									
Tigra/Tigra-B	Engine	C 14 SE																																									
Tigra/Tigra-B	Engine	Z 14 XE																																									
Tigra/Tigra-B	Engine	Z 14 XEP																																				V					
Tigra/Tigra-B	Engine	Z 16 SE																																									
Tigra/Tigra-B	Engine	Z 18 XE																																									
Tigra/Tigra-B	Transmission	AF 13/14/20																																									
Tigra/Tigra-B	Transmission	AF 13II/20/22/30																																									
Tigra/Tigra-B	Transmission	AF 13-II/17/20/22 CAN																																									
Tigra/Tigra-B	Chassis	ABS 5.3/5.4 +TC																																									
Tigra/Tigra-B	Chassis	ABS/ESP8																																									
Tigra/Tigra-B	Chassis	Electronic Power Steering																																									
Tigra/Tigra-B	Body	Immobiliser																																									
Tigra/Tigra-B	Body	Body Control Module																																									
Tigra/Tigra-B	Body	SRS Airbag																																									
Tigra/Tigra-B	Body	Instrument																																									
Tigra/Tigra-B	Information	Read security PIN code															V																										
Tigra/Tigra-B	Information	Trip info display																																									
Vectra/Vectra-B	Engine	C 20 SEL																																									
Vectra/Vectra-B	Engine	C 22 SEL																																									
Vectra/Vectra-B	Engine	Z 22 SE																																									
Vectra/Vectra-B	Engine	X 25 XE																																									
Vectra/Vectra-B	Engine	Y 26 SE																																									
Vectra/Vectra-B	Transmission	AF 13/14/20																																									
Vectra/Vectra-B	Transmission	AF 13II/20/22/30																																									
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22																																									
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22 CAN																																									
Vectra/Vectra-B	Chassis	ABS 5.3/5.4 +TC																																									

Model	Group	System	Yaw rate sensor learn	Transmission adaptive pressure reset	Remote vehicle start disabled history reset	APP Learn	Clutch Pedal Position Learn	Fuel Injector Balance	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Engine Oil Life Reset	Fuel trim reset	Fuel Composition Reset	BCM link to ECM/Immobilizer	Instrument link to ECM/Immobilizer	Read security PIN code	Brake pedal position sensor learn	Range actuator learn	Transmission adaptive pressure reset	Read BCM Security code	Power steering soft stop reset	Power steering soft stop learn	Steering Wheel Angle Sensor Centering (Not Equipped Only)	History of alarm	Button diagnosis	Transmitter coding	Key diagnosis	Key coding	Immobilizer link to ECM	Reset ECU	PIM install(GEN III)	PIM install(V8 GEN IV)	RESET SERVICE INTERVAL	Program Variant Configuration	BCM Security Information and Program	Program New Remote Key	BCM Link to PCM(PIM)	Reset O2 loop block learn map	VIN Programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)
Vectra/Vectra-B	Body	Immobiliser																																										
Vectra/Vectra-B	Body	SRS Airbag SAB6																																										
Vectra/Vectra-B	Body	Central Door Lock																																										
Vectra/Vectra-B	Body	Instrument																																										
Vectra/Vectra-B	Information	Read security PIN code															V																											
Vectra/Vectra-B	Infotainment System	Trip info display																																										
Vectra/Vectra-C	Engine	Z 32 SE																																										
Vectra/Vectra-C	Transmission	AF 23-5/33-5/40-6																													V													
Vectra/Vectra-C	Chassis	ABS/TC/ESP																																										
Vectra/Vectra-C	Chassis	EHPS(Electrohydraulic power steering)																																										
Vectra/Vectra-C	Body	SDM(Airbag)																																										
Vectra/Vectra-C	Body	CIM(Steering column module)																																										
Vectra/Vectra-C	Body	BCM(Body control module)																																										
Vectra/Vectra-C	Body	IPC(Instrument control unit)																																										
Vectra/Vectra-C	Body	REC(Rear electrical control)																																										
Vectra/Vectra-C	Body	UEC(Underhood electrical control)																																										
Vectra/Vectra-C	Body	DDM(Driver door module)																																										
Vectra/Vectra-C	Body	PDM(Passenger door module)																																										
Vectra/Vectra-C	Body	SLM(Shift lever module)																																										
Vectra/Vectra-C	Body	Electronic seat																																										
Vectra/Vectra-C	Information	Read security PIN code															V																											
Zafira/2001-2005	Engine	Z 22 SE																																				V						
Zafira/2001-2005	Transmission	AF 13-II/17/20/22 CAN																																										
Zafira/2001-2005	Chassis	ABS 5.3/5.4 +TC																																										
Zafira/2001-2005	Chassis	Electronic Power Steering																																										
Zafira/2001-2005	Body	Immobiliser																																										
Zafira/2001-2005	Body	SRS Airbag																																										
Zafira/2001-2005	Body	Instrument																																										
Zafira/2001-2005	Body	Engine Cooling Module																																										
Zafira/2001-2005	Body	Central Door Lock																																										
Zafira/2001-2005	Information	Read security PIN code															V																											
Zafira/2001-2005	Infortainment System	Trip Info Display																																										

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
Commodore/VR	Engine	V6/V8																																									
Commodore/VR	Transmission	A/T																																									
Commodore/VR	Chassis	ABS																																									
Commodore/VR	Body	SRS Airbag																																									
Commodore/VR	Body	BCM(Body control module)																																									
Commodore/VR	Body	TDM																																									
Commodore/VS	Engine	V6																																									
Commodore/VS	Engine	V8																																									
Commodore/VS	Transmission	V6 A/T																																									
Commodore/VS	Transmission	V8 A/T																																									
Commodore/VS	Chassis	ABS																																									
Commodore/VS	Body	SRS Airbag																																									
Commodore/VS	Body	BCM(Body control module)																																									
Commodore/VT(Include VSv8)	Engine	V6																																									
Commodore/VT(Include VSv8)	Engine	V8																																									
Commodore/VT(Include VSv8)	Engine	V8 GEN III																																									
Commodore/VT(Include VSv8)	Transmission	A/T																																									
Commodore/VT(Include VSv8)	Transmission	A/T GEN III																																									
Commodore/VT(Include VSv8)	Chassis	ABS																																									
Commodore/VT(Include VSv8)	Body	SRS Airbag																																									
Commodore/VT(Include VSv8)	Body	BCM(Body control module)																																									
Commodore/VT(Include VSv8)	Body	Instrument																																									
Commodore/VT(Include VSv8)	Body	PIM(Powertrain Interface Module)																																									
Commodore/VT(Include VSv8)	Body	Climate Control																																									
Commodore/VX	Engine	V6																																									
Commodore/VX	Engine	V6 Supercharged																																									
Commodore/VX	Engine	V8 GEN III																																									
Commodore/VX	Transmission	A/T																																									
Commodore/VX	Transmission	A/T GEN III																																									
Commodore/VX	Chassis	ABS																																									
Commodore/VX	Body	SRS Airbag																																									
Commodore/VX	Body	BCM(Body control module)																																									
Commodore/VX	Body	Instrument																																									
Commodore/VX	Body	PIM(Powertrain Interface Module)																																									
Commodore/VX	Body	Climate Control																																									
Commodore/VY	Engine	V6																																									
Commodore/VY	Engine	V6 Supercharged																																									
Commodore/VY	Engine	V8 GEN III																																									

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
Commodore/VY	Transmission	A/T																																									
Commodore/VY	Transmission	A/T GEN III																																									
Commodore/VY	Chassis	ABS																																									
Commodore/VY	Body	SRS Airbag																																									
Commodore/VY	Body	BCM(Body control module)																																									
Commodore/VY	Body	Instrument																																									
Commodore/VY	Body	PIM(Powertrain Interface Module)																																									
Commodore/VY	Body	Audio System																																									
Commodore/VZ	Engine	V6										V												V																			
Commodore/VZ	Engine	V6 Supercharged																																									
Commodore/VZ	Engine	V8 GEN III																																									
Commodore/VZ	Engine	V8 GEN IV																																									
Commodore/VZ	Transmission	A/T																																									
Commodore/VZ	Transmission	A/T GEN III																																									
Commodore/VZ	Chassis	ABS/TC/ESP8.0																																									
Commodore/VZ	Chassis	ABS/ETC																																									
Commodore/VZ	Body	SRS Airbag																																									
Commodore/VZ	Body	BCM(Body control module)																																									
Commodore/VZ	Body	PIM(Powertrain Interface Module)																																									
Commodore/VZ	Body	Instrument																																									
Commodore/VZ	Body	Audio System																																									
Commodore/VE	Engine	V6									V							V						V																			
Commodore/VE	Engine	V8 GEN IV																																									
Commodore/VE	Transmission	A/T																																									
Commodore/VE	Chassis	EBCM(Electronic brake control module)																																									
Commodore/VE	Chassis	TPMS(Tyre pressure monitor system)												V	V																												
Commodore/VE	Chassis	Fuel Pump Control																																									
Commodore/VE	Body	BCM(Body control module)																																									
Commodore/VE	Body	VTM(Theft deterrent module)																																									
Commodore/VE	Body	RFA(Remote function actuator)																																									
Commodore/VE	Body	SDM(SRS Airbag)																																									
Commodore/VE	Body	IPC(Instrument Panel Cluster)																																									
Commodore/VE	Body	HVAC(Heating Ventilating and Air Conditioning)																																									
Commodore/VE	Body	MSM																																									
Commodore/VE	Body	Parking Assist																																									
Commodore/VE	Body	AHL																																									
Commodore/VE	Infotainment System	Audio System																																									
Commodore/VE	Infotainment System	Rear Seat Entertainment																																									

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
VF Comodore	Powertrain	3.0L LFW(Beta)																																									
VF Comodore	Powertrain	3.6L LFX																																									
VF Comodore	Powertrain	6.2L LS3(Beta)																																									
VF Comodore	Powertrain	FICM(Fuel injector control module)																																									
VF Comodore	Powertrain	TCM(Transmission control unit)																																									
VF Comodore	Chassis	CCM(Chassis control module)																																									
VF Comodore	Chassis	EBCM(Electronic brake control module)																																									
VF Comodore	Chassis	PBCM(Parking brake control module)																																									
VF Comodore	Chassis	PSCM(Power steering control module)																																									
VF Comodore	Chassis	SWASM(Steering wheel angle sensor module)																																									
VF Comodore	Chassis	SCM(Suspension control module)																																									
VF Comodore	Body	Immobilizer																																									
VF Comodore	Body	BCM(Body control module)																																									
VF Comodore	Body	SDM(Inflatable restraint sensing and diagnostic module)																																									
VF Comodore	Body	IC(Instrument cluster)																																									
VF Comodore	Body	HDM(Head-up display module)																																									
VF Comodore	Body	RCP(Radio control panel)																																									
VF Comodore	Body	HVACCP(Heating Ventilating and Air Conditioning control panel)																																									
VF Comodore	Body	Radio																																									
VF Comodore	Body	HVAC(Heating Ventilating and Air Conditioning)																																									
VF Comodore	Body	RODCM(Right side object detection control module)																																									
VF Comodore	Body	LODCM(Left side object detection control module)																																									
VF Comodore	Body	Keyless																																									
VF Comodore	Body	PACM(Parking assist control module)																																									
VF Comodore	Body	FVCM(Front view camera module)																																									
VF Comodore	Body	SCCM(Steering column lock control module)																																									
YG Cruze		Engine																																									
YG Cruze		Transmission																																									
YG Cruze		ABS																																									
YG Cruze		EPS																																									
YG Cruze		Immobilizer																																									
YG Cruze		Airbag																																									
Cruze/Gasoline	Powertrain	Engine control module(1.4L LUJ)														V	V	V	V	V				V																			
Cruze/Gasoline	Powertrain	Engine control module(1.8L 2H0)																																								V	
Cruze/Gasoline	Powertrain	Fuel pump control module																						V																			
Cruze/Gasoline	Powertrain	Transmission control module																																									
Cruze/Gasoline	Chassis	EBCM(Electronic brake control module)	V	V	V																																						
Cruze/Gasoline	Chassis	Multi-Axis acceleration sensor module		V		V																																					

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
Cruze/Gasoline	Chassis	Steering wheel angle sensor module	V				V																																				
Cruze/Gasoline	Chassis	Electrinic power steering control module																																									
Cruze/Gasoline	Body	Body control module																																									
Cruze/Gasoline	Body	Immobilizer																																									
Cruze/Gasoline	Body	SDM(Inflatable restraint sensing and diagnostic module)																																									
Cruze/Gasoline	Body	Passenger presence module																																									
Cruze/Gasoline	Body	Instrument panel cluster																																									
Cruze/Gasoline	Body	Auto Heating ventilating and air conditioning																																									
Cruze/Gasoline	Body	Manual Heating ventilating and air conditioning																																									
Cruze/Gasoline	Body	Front seat heating control module																																									
Cruze/Gasoline	Body	Park assist control module																																									
Cruze/Gasoline	Body	Passive entry passive start																																									
Cruze/Gasoline	Body	Steering column lock control module																																									
Cruze/Gasoline	Infotainment	Radio																																									
Cruze/Gasoline	Infotainment	Telematics communication interface control module																																									
Cruze/Diesel	Powertrain	Engine control module(2.0L LLW)																							V					V			V										
Cruze/Diesel	Powertrain	Engine control module(2.0L LNP)																							V			V	V	V	V	V	V										
Cruze/Diesel	Powertrain	Fuel pump control module																																									
Cruze/Diesel	Powertrain	Transmission control module																																									
Cruze/Diesel	Chassis	EBCM(Electronic brake control module)	V	V	V																																						
Cruze/Diesel	Chassis	Multi-Axis acceleration sensor module		V		V																																					
Cruze/Diesel	Chassis	Steering wheel angle sensor module	V				V																																				
Cruze/Diesel	Chassis	Electrinic power steering control module																																									
Cruze/Diesel	Body	Body control module																																									
Cruze/Diesel	Body	Immobilizer																																									
Cruze/Diesel	Body	SDM(Inflatable restraint sensing and diagnostic module)																																									
Cruze/Diesel	Body	Passenger presence module																																									
Cruze/Diesel	Body	Instrument panel cluster																																									
Cruze/Diesel	Body	Auto Heating ventilating and air conditioning																																									
Cruze/Diesel	Body	Manual Heating ventilating and air conditioning																																									
Cruze/Diesel	Body	Front seat heating control module																																									
Cruze/Diesel	Body	Park assist control module																																									
Cruze/Diesel	Body	Passive entry passive start																																									
Cruze/Diesel	Body	Steering column lock control module																																									
Cruze/Diesel	Infotainment	Radio																																									
Cruze/Diesel	Infotainment	Telematics communication interface control module																																									
Barina/Spark/Barina(T300)	Powertrain	Engine control module(1.4L LUJ)														V	V	V	V	V				V																			
Barina/Spark/Barina(T300)	Powertrain	Engine control unit(1.6L LDE)														V	V	V		V				V																			

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
Barina/Spark/Barina(T300)	Powertrain	TCM(Transmission control module)																																									
Barina/Spark/Barina(T300)	Chassis	Electronic brake control module																																									
Barina/Spark/Barina(T300)	Chassis	Multi-Axis acceleration sensor module		V		V																																					
Barina/Spark/Barina(T300)	Chassis	Steering wheel angle sensor module	V				V																																				
Barina/Spark/Barina(T300)	Body	Immobilizer																																									
Barina/Spark/Barina(T300)	Body	BCM(Body control module)																																V									
Barina/Spark/Barina(T300)	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																									
Barina/Spark/Barina(T300)	Body	IPC(Instrument Cluster)																																									
Barina/Spark/Barina(T300)	Information	Radio																																									
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LEB)																																							V	V
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LMT)														V																										
Barina/Spark/Barina Spark	Powertrain	Engine LPG																																									
Barina/Spark/Barina Spark	Powertrain	TCM(Transmission control module)																																									
Barina/Spark/Barina Spark	Chassis	Electronic brake control module																																									
Barina/Spark/Barina Spark	Chassis	Multi-Axis acceleration sensor module		V		V																																					
Barina/Spark/Barina Spark	Chassis	Electronic power steering control module																																									
Barina/Spark/Barina Spark	Chassis	Steering wheel angle sensor module	V				V																																				
Barina/Spark/Barina Spark	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																									
Barina/Spark/Barina Spark	Body	IPC(Instrument Cluster)																																									
Barina/Spark/Barina Spark	Body	Keyless entry control module																																									
Barina/Spark/Barina Spark	Body	Passenger presensce module																																									
Barina/Spark/Barina(OPEL)	Engine	C 14 SE																																									
Barina/Spark/Barina(OPEL)	Engine	Z 14 XE																																									
Barina/Spark/Barina(OPEL)	Engine	Z 14 XEP																																									
Barina/Spark/Barina(OPEL)	Engine	Z 16 SE																																									
Barina/Spark/Barina(OPEL)	Engine	Z 18 XE																																									
Barina/Spark/Barina(OPEL)	Transmission	AF 13/14/20																																									
Barina/Spark/Barina(OPEL)	Transmission	AF 13II/20/22/30																																									
Barina/Spark/Barina(OPEL)	Transmission	AF 13-II/17/20/22 CAN																																									
Barina/Spark/Barina(OPEL)	Chassis	ABS 5.3/5.4 +TC																																									
Barina/Spark/Barina(OPEL)	Chassis	ABS/ESP8																																									
Barina/Spark/Barina(OPEL)	Chassis	Electronic Power Steering																																									
Barina/Spark/Barina(OPEL)	Body	Immobiliser																																									
Barina/Spark/Barina(OPEL)	Body	Body Control Module						V	V																																		
Barina/Spark/Barina(OPEL)	Body	SRS Airbag																																									
Barina/Spark/Barina(OPEL)	Body	Instrument																																									
Barina/Spark/Barina(OPEL)	Information	Read security PIN code																																									
Barina/Spark/Barina(OPEL)	Information	Trip info display																																									

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.5 Sohc																																									
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.6 Dohc											V																														
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	A/T Aisin5																																									
Barina/Spark/Barina(GM/DAEWOO)	Chassis	ABS								V																																	
Barina/Spark/Barina(GM/DAEWOO)	Body	Immobilizer																																									
Barina/Spark/Barina(GM/DAEWOO)	Body	Keyless entry																																									
Barina/Spark/Barina(GM/DAEWOO)	Body	Air Bag																																									
Volt		ECM(Engine control module)																																									
Volt		FPCM(Fuel pump control module)																																									
Volt		HVCM(Hybrid powertrain control module)																																									
Volt		HVCM2(Hybrid powertrain control module 2)																																									
Volt		TCM(Transmission control module)																																									
Volt		DMCM1(Driver motor control module 1)																																									
Volt		DMCM2(Driver motor control module 2)																																									
Volt		BCCM(Battery charger control module)																																									
Volt		BECM(Battery energy control module)																																									
Volt		ATFP(Auxiliary transmission fluid pump)																																									
Volt		EBCM(Electronic brake control module)																																									
Volt		PBCM(Parking brake control module)																																									
Volt		MAASM(Multi axis acceleration sensor module)																																									
Volt		PSCM(Power steering control module)																																									
Volt		SWASM(Steering wheel angle sensor module)																																									
Volt		Immobilizer																																									
Volt		BCM(Body control module)																																									
Volt		SDM(Inflatable restraint sensing and diagnostic module)																																									
Volt		IC(Instrument cluster)																																									
Volt		Radio																																									
Volt		TCIC(Telematics communication interface control module)																																									
Volt		HVAC(Heating Ventilating and Air Conditioning)																																									
Volt		CHCM(Coolant heater control module)																																									
Volt		SHCM(Seat heating control module)																																									
Volt		Keyless																																									
Volt		PACM(Parking assist control module)																																									
Volt		FVC(Front view camera)																																									
Volt		SCCM(Steering column lock control module)																																									
Captiva/Captiva	Powertrain	Engine Diesel																																									
Captiva/Captiva	Powertrain	Engine 2.4 Dohc																																									
Captiva/Captiva	Powertrain	Engine 3.2 Dohc																						V									V										

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
Captiva/Captiva	Powertrain	Auto Transmission																																									
Captiva/Captiva	Chassis	EBCM(Electronic brake control module)																																									
Captiva/Captiva	Chassis	TCCM(Transfer case control module)																																									
Captiva/Captiva	Body	SDM(SRS Airbag)																																									
Captiva/Captiva	Body	IPC(Instrument panel cluster)																																									
Captiva/Captiva	Body	BCM(Body control module)																																									
Captiva/Captiva	Body	VTD(Theft deterrent module)																																									
Captiva/Captiva	Body	RFA(Remote function actuator)																																	V	V	V	V	V	V			
Captiva/Captiva 5/7	Powertrain	Engine control module(2.2L LNQ)																							V			V	V	V	V	V	V										
Captiva/Captiva 5/7	Powertrain	Engine control module(2.4L LE5)														V	V	V		V				V																			
Captiva/Captiva 5/7	Powertrain	Engine control module(3.0L LF1)														V	V	V	V	V				V																			
Captiva/Captiva 5/7	Powertrain	Fuel pump control module																																									
Captiva/Captiva 5/7	Powertrain	Transmission control module																																									
Captiva/Captiva 5/7	Chassis	Electronic brake control module	V																																								
Captiva/Captiva 5/7	Chassis	Parking brake control module																																						V			
Captiva/Captiva 5/7	Chassis	Rear differential clutch control module																																									
Captiva/Captiva 5/7	Body	Body control module																																V									
Captiva/Captiva 5/7	Body	Inflatable restraint sensing and diagnostic module																																									
Captiva/Captiva 5/7	Body	Instrument panel cluster																																									
Captiva/Captiva 5/7	Body	HVAC control module																																									
Captiva/Captiva 5/7	Body	Remote control door lock receiver																																	V	V	V	V	V	V			
Captiva/Captiva 5/7	Body	Theft deterrent module																																									
Captiva/Captiva 5/7	Body	Parking assist control module																																									
Captiva/Captiva 5/7	Infotainment	Radio																																									
VIVA		1.4/1.5 Dohc																																									
VIVA		1.6 Dohc																																									
VIVA		1.8 Dohc											V																														
VIVA		A/T																																									
VIVA		ABS																																									
VIVA		SSPS																																									
VIVA		Immobilizer																																									
VIVA		Keyless entry																																									
VIVA		Air Bag																																									
Malibu		ECM 2.4L(Engine control module 2.4L LE9)																																									
Malibu		ECM 2.0L(Engine control module 2.0L LBS)															V			V					V	V	V	V	V		V												V
Malibu		TCM(Transmission control module)																																									
Malibu		EBCM(Electronic brake control module)																																									
Malibu		MAASM(Multi axis acceleration sensor module)																																									

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
Malibu		PSCM(Power steering control module)																																									
Malibu		SWASM(Steering wheel angle sensor module)																																									
Malibu		Immobilizer																																									
Malibu		BCM(Body control module)																																									
Malibu		SDM(Inflatable restraint sensing and diagnostic module)																																									
Malibu		IC(Instrument cluster)																																									
Malibu		Radio																																									
Malibu		HVAC(Heating Ventilating and Air Conditioning)																																									
Malibu		Keyless																																									
Malibu		PACM(Parking assist control module)																																									
Malibu		SCCM(Steering column lock control module)																																									
Epica		2.0 Dohc(Beta)																																									
Epica		Engine Diesel																																									
Epica		A/T Aisin5(Beta)																																									
Epica		A/T GF 6																																									
Epica		ABS																																									
Epica		SSPS																																									
Epica		SDM(SRS AIRBAG)																																									
Epica		Keyless entry																																									
Epica		ISU/BCM																																									
Astra/Astra-F	Engine	C16SE																																									
Astra/Astra-F	Engine	C18SEL																																									
Astra/Astra-F	Transmission	AF 13/14/20																																									
Astra/Astra-F	Transmission	AF 13II/20/22/30																																									
Astra/Astra-F	Body	Immobilizer																																									
Astra/Astra-F	Body	Airbag-S																																									
Astra/Astra-G	Engine	Z 18 XE																																									
Astra/Astra-G	Engine	X 18 XE1																																									
Astra/Astra-G	Engine	Z 22 SE																																									
Astra/Astra-G	Transmission	AF 13-II/17/20/22																																									
Astra/Astra-G	Transmission	AF 13-II/17/20/22 CAN																																									
Astra/Astra-G	Chassis	ABS 5.3/5.4 +TC																																									
Astra/Astra-G	Chassis	ESP																																									
Astra/Astra-G	Chassis	Electronic Power Steering																																									
Astra/Astra-G	Body	Immobiliser																																									
Astra/Astra-G	Body	SRS Airbag																																									
Astra/Astra-G	Body	Instrument																																									
Astra/Astra-G	Body	Engine Cooling Module																																									

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
Astra/Astra-G	Body	Add On Heater																																									
Astra/Astra-G	Body	Electronic Climate Control																																									
Astra/Astra-G	Body	Central Door Lock							V																																		
Astra/Astra-G	Body	Softtop Controller																																									
Astra/Astra-G	Information	Read security PIN code																																									
Astra/Astra-G	Infortainment System	Trip Info Display																																									
Astra/Astra-G	Infortainment System	Multi Info Display																																									
Astra/Astra-H	Engine	Z 18 XE																																									
Astra/Astra-H	Engine	Z 18 XER																																									
Astra/Astra-H	Engine	Z 19 DT(Beta)																							V																		
Astra/Astra-H	Engine	Z 20 LEH																																									
Astra/Astra-H	Engine	Z 20 LER																																									
Astra/Astra-H	Engine	Z 22 YH																																									
Astra/Astra-H	Transmission	AF 40-6(Beta)																																									
Astra/Astra-H	Transmission	AF 22-4																																									
Astra/Astra-H	Transmission	AF 17-4																																									
Astra/Astra-H	Chassis	ABS/TC/ESP																																									
Astra/Astra-H	Chassis	EHPS(Electrohydraulic power steering)																																									
Astra/Astra-H	Body	SDM(Airbag)																																									
Astra/Astra-H	Body	CIM(Steering column module)																																									
Astra/Astra-H	Body	IPC(Instrument control unit)																																									
Astra/Astra-H	Body	UEC(Underhood electrical centre)																																									
Astra/Astra-H	Body	REC(Rear electrical centre)																																									
Astra/Astra-H	Body	PAS(Park pilot)																																									
Astra/Astra-H	Body	SAC(Air conditioning)																																									
Astra/Astra-H	Body	Electrohydraulic hard top																																									
Combo/Corsa-B	Engine	C 14 SE																																									
Combo/Corsa-B	Engine	Z 14 XE																																									
Combo/Corsa-B	Engine	Z 14 XEP																																									
Combo/Corsa-B	Engine	Z 16 SE																																									
Combo/Corsa-B	Engine	Z 18 XE																																									
Combo/Corsa-B	Transmission	AF 13/14/20																																									
Combo/Corsa-B	Transmission	AF 13II/20/22/30																																									
Combo/Corsa-B	Transmission	AF 13-II/17/20/22 CAN																																									
Combo/Corsa-B	Chassis	ABS 5.3/5.4 +TC																																									
Combo/Corsa-B	Chassis	ABS/ESP8																																									
Combo/Corsa-B	Chassis	Electronic Power Steering																																									
Combo/Corsa-B	Body	Immobiliser																																									

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
Combo/Corsa-B	Body	Body Control Module						V	V																																			
Combo/Corsa-B	Body	SRS Airbag																																										
Combo/Corsa-B	Body	Instrument																																										
Combo/Corsa-B	Information	Trip info display																																										
Combo/Corsa-C	Engine	Z 14 XE																																										
Combo/Corsa-C	Engine	Z 14 XEP																																										
Combo/Corsa-C	Engine	Z 16 SE																																										
Combo/Corsa-C	Engine	Z 18 XE																																										
Combo/Corsa-C	Transmission	AF 13-II/17/20/22 CAN																																										
Combo/Corsa-C	Chassis	ABS 5.3/5.4 +TC																																										
Combo/Corsa-C	Chassis	Electronic Power Steering																																										
Combo/Corsa-C	Body	Immobiliser																																										
Combo/Corsa-C	Body	Body Control Module						V	V																																			
Combo/Corsa-C	Body	SRS Airbag																																										
Combo/Corsa-C	Body	Instrument																																										
Combo/Corsa-C	Information	Read security PIN code																																										
Trax		Engine Control Module 1.4L - 2WD																																										
Trax		Engine Control Module 1.4L - AWD																																										
Trax		Engine Control Module 1.8L - 2WD																																										
Trax		Engine Control Module 1.8L - AWD																																										
Trax		Engine Control Module 1.7L																			V	V	V		V			V	V			V												
Trax		Transmission																																										
Trax		Rear Differential Clutch Control Module - Beta																																										
Trax		EBCM(Electronic brake control module)																																										
Trax		PSCM(Power steering control module)																																										
Trax		SWASM(Steering wheel angle sensor module)																																										
Trax		Immobilizer																																										
Trax		BCM(Body control module)																																										
Trax		SDM(Inflatable restraint sensing and diagnostic module)																																										
Trax		IC(Instrument cluster)																																										
Trax		Radio																																										
Trax		HVAC(Heating Ventilating and Air Conditioning)																																										
Trax		SHCM(Seat heating control module)																																										
Trax		PACM(Parking assist control module)																																										
Jackaroo/Monterey	Engine	6VD1																																										
Jackaroo/Monterey	Engine	3.0 L4 4JX1																																										
Jackaroo/Monterey	Engine	3.2 V6 6VD1 Hitachi																																										
Jackaroo/Monterey	Engine	3.5 V6 6VE1 Hitachi									V	V												V																				

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
Jackaroo/Monterey	Transmission	4L30E																																									
Jackaroo/Monterey	Transmission	AW30-40LE																																									
Jackaroo/Monterey	Body	Immobilizer																																									
Jackaroo/Monterey	Body	Airbag																																									
Jackaroo/Monterey	Body	Aniti theft warning						V	V																																		
Rodeo/Colorado/Rodeo	Engine	6VD1																																									
Rodeo/Colorado/Rodeo	Engine	2.2 L4 SOHC																																									
Rodeo/Colorado/Rodeo	Engine	2.X L4 HV240									V	V	V																														
Rodeo/Colorado/Rodeo	Engine	3.2 V6 6VD1 Hitachi																																									
Rodeo/Colorado/Rodeo	Transmission	4L30E																																									
Rodeo/Colorado/Rodeo	Transmission	AW30-40LE																																									
Rodeo/Colorado/Rodeo	Body	Immobilizer																																									
Rodeo/Colorado/Rodeo	Body	Aniti theft warning						V	V																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.2 L4 SOHC																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.4 LP1 EURO3																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.X L4 HV240									V	V	V																														
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.0 iTD(4JH1-TC)									V	V																															
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.5 V6 6VE1 Hitachi									V	V												V																			
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	V6 Engine										V												V																			
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AT JR405E																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AW30-40LE																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	Auto transmission																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Chassis	ABS																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Immobilizer																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	PIM(Powertrain interface module)																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	SRS airbag																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Aniti theft warning						V	V																																		
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	2.4 LP1 EURO3																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Delphi)																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Transtron)																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	V6 Engine										V												V																			
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Chassis	ABS																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	AW30-40LE																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	Auto transmission																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Immobilizer(V6 Engine)																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	SRS(Airbag)																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Aniti theft warning						V	V																																		
New Colorado/Colorado7	Engine	2.8L Diesel(LWH)																														V											

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU4																															V										
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU5																															V										
New Colorado/Colorado7	Chassis	Electronic brake control module																																									
New Colorado/Colorado7	Chassis	Transfer case control module																																									
New Colorado/Colorado7	Chassis	Steering wheel angle sensor module	V					V																																			
New Colorado/Colorado7	Chassis	Multi-Axis acceleration sensor module		V			V																																				
New Colorado/Colorado7	Transmission	Auto transmission(6SP)																																									
New Colorado/Colorado7	Body	Immobilizer(New Colorado)																																									
New Colorado/Colorado7	Body	Body Control Module																																									
New Colorado/Colorado7	Body	Instrument cluster																																									
New Colorado/Colorado7	Body	SRS(Airbag)																																									
Tigra/Tigra-B	Engine	C 14 SE																																									
Tigra/Tigra-B	Engine	Z 14 XE																																									
Tigra/Tigra-B	Engine	Z 14 XEP																																									
Tigra/Tigra-B	Engine	Z 16 SE																																									
Tigra/Tigra-B	Engine	Z 18 XE																																									
Tigra/Tigra-B	Transmission	AF 13/14/20																																									
Tigra/Tigra-B	Transmission	AF 13II/20/22/30																																									
Tigra/Tigra-B	Transmission	AF 13-II/17/20/22 CAN																																									
Tigra/Tigra-B	Chassis	ABS 5.3/5.4 +TC																																									
Tigra/Tigra-B	Chassis	ABS/ESP8																																									
Tigra/Tigra-B	Chassis	Electronic Power Steering																																									
Tigra/Tigra-B	Body	Immobiliser																																									
Tigra/Tigra-B	Body	Body Control Module						V	V																																		
Tigra/Tigra-B	Body	SRS Airbag																																									
Tigra/Tigra-B	Body	Instrument																																									
Tigra/Tigra-B	Information	Read security PIN code																																									
Tigra/Tigra-B	Information	Trip info display																																									
Vectra/Vectra-B	Engine	C 20 SEL																																									
Vectra/Vectra-B	Engine	C 22 SEL																																									
Vectra/Vectra-B	Engine	Z 22 SE																																									
Vectra/Vectra-B	Engine	X 25 XE																																									
Vectra/Vectra-B	Engine	Y 26 SE																																									
Vectra/Vectra-B	Transmission	AF 13/14/20																																									
Vectra/Vectra-B	Transmission	AF 13II/20/22/30																																									
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22																																									
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22 CAN																																									
Vectra/Vectra-B	Chassis	ABS 5.3/5.4 +TC																																									

Model	Group	System	Steering Wheel Angle Sensor Learn	Yaw Rate Sensor Learn	Brake Pressure Sensor Calibration	Yaw Rate Sensor Reset	Steering Wheel Angle Sensor Reset	Program remote keys	Erase remote keys	Brake bleed	Program immobilizer function	Reset ECM	IAC Reset	TPMS Learn mode	TPMS Initialization	Crankshaft position variant learn	HO2S Heater learn	Idle learn	Brake pedal position sensor learn	Eingine oil life reset	Cylinder Power Balance	DPF Pressure Sensor Reset	Idle Air Control Reset	Fuel trim reset	DPF Regeneration	DPF Regeneration status	DPF Incomplate regeneration status	DPF reset	Injector flow rate programming	Clutch pedal position learn	Intake manifold runner control valve learn	Fuel pressure regulator learn	Engine oil life reset	Brake Pedal Position Sensor Learn	Erase All Key Fobs	Next Available Slot	Key Fob 1	Key Fob 2	Key Fob 3	Key Fob 4	Park brake calibration	Engine Oil Life Reset	Glow Plug Control Module Reset
Vectra/Vectra-B	Body	Immobiliser																																									
Vectra/Vectra-B	Body	SRS Airbag SAB6																																									
Vectra/Vectra-B	Body	Central Door Lock							V																																		
Vectra/Vectra-B	Body	Instrument																																									
Vectra/Vectra-B	Information	Read security PIN code																																									
Vectra/Vectra-B	Infotainment System	Trip info display																																									
Vectra/Vectra-C	Engine	Z 32 SE																																									
Vectra/Vectra-C	Transmission	AF 23-5/33-5/40-6																																									
Vectra/Vectra-C	Chassis	ABS/TC/ESP																																									
Vectra/Vectra-C	Chassis	EHPS(Electrohydraulic power steering)																																									
Vectra/Vectra-C	Body	SDM(Airbag)																																									
Vectra/Vectra-C	Body	CIM(Steering column module)																																									
Vectra/Vectra-C	Body	BCM(Body control module)																																									
Vectra/Vectra-C	Body	IPC(Instrument control unit)																																									
Vectra/Vectra-C	Body	REC(Rear electrical control)																																									
Vectra/Vectra-C	Body	UEC(Underhood electrical control)																																									
Vectra/Vectra-C	Body	DDM(Driver door module)																																									
Vectra/Vectra-C	Body	PDM(Passenger door module)																																									
Vectra/Vectra-C	Body	SLM(Shift lever module)																																									
Vectra/Vectra-C	Body	Electronic seat																																									
Vectra/Vectra-C	Information	Read security PIN code																																									
Zafira/2001-2005	Engine	Z 22 SE																																									
Zafira/2001-2005	Transmission	AF 13-II/17/20/22 CAN																																									
Zafira/2001-2005	Chassis	ABS 5.3/5.4 +TC																																									
Zafira/2001-2005	Chassis	Electronic Power Steering																																									
Zafira/2001-2005	Body	Immobiliser																																									
Zafira/2001-2005	Body	SRS Airbag																																									
Zafira/2001-2005	Body	Instrument																																									
Zafira/2001-2005	Body	Engine Cooling Module																																									
Zafira/2001-2005	Body	Central Door Lock							V																																		
Zafira/2001-2005	Information	Read security PIN code																																									
Zafira/2001-2005	Infortainment System	Trip Info Display																																									

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
Commodore/VR	Engine	V6/V8																																									
Commodore/VR	Transmission	A/T																																									
Commodore/VR	Chassis	ABS																																									
Commodore/VR	Body	SRS Airbag																																									
Commodore/VR	Body	BCM(Body control module)																																									
Commodore/VR	Body	TDM																																									
Commodore/VS	Engine	V6																																									
Commodore/VS	Engine	V8																																									
Commodore/VS	Transmission	V6 A/T																																									
Commodore/VS	Transmission	V8 A/T																																									
Commodore/VS	Chassis	ABS																																									
Commodore/VS	Body	SRS Airbag																																									
Commodore/VS	Body	BCM(Body control module)																																									
Commodore/VT(Include VSv8)	Engine	V6																																									
Commodore/VT(Include VSv8)	Engine	V8																																									
Commodore/VT(Include VSv8)	Engine	V8 GEN III																		V																							
Commodore/VT(Include VSv8)	Transmission	A/T																																									
Commodore/VT(Include VSv8)	Transmission	A/T GEN III																																									
Commodore/VT(Include VSv8)	Chassis	ABS																																									
Commodore/VT(Include VSv8)	Body	SRS Airbag																																									
Commodore/VT(Include VSv8)	Body	BCM(Body control module)																																									
Commodore/VT(Include VSv8)	Body	Instrument																																									
Commodore/VT(Include VSv8)	Body	PIM(Powertrain Interface Module)																																									
Commodore/VT(Include VSv8)	Body	Climate Control																																									
Commodore/VX	Engine	V6																																									
Commodore/VX	Engine	V6 Supercharged																																									
Commodore/VX	Engine	V8 GEN III																		V																							
Commodore/VX	Transmission	A/T																																									
Commodore/VX	Transmission	A/T GEN III																																									
Commodore/VX	Chassis	ABS																																									
Commodore/VX	Body	SRS Airbag																																									
Commodore/VX	Body	BCM(Body control module)																																									
Commodore/VX	Body	Instrument																																									
Commodore/VX	Body	PIM(Powertrain Interface Module)																																									
Commodore/VX	Body	Climate Control																																									
Commodore/VY	Engine	V6																																									
Commodore/VY	Engine	V6 Supercharged																																									
Commodore/VY	Engine	V8 GEN III																		V																							

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
Commodore/VY	Transmission	A/T																																										
Commodore/VY	Transmission	A/T GEN III																																										
Commodore/VY	Chassis	ABS																																										
Commodore/VY	Body	SRS Airbag																																										
Commodore/VY	Body	BCM(Body control module)																																										
Commodore/VY	Body	Instrument																																										
Commodore/VY	Body	PIM(Powertrain Interface Module)																																										
Commodore/VY	Body	Audio System																																										
Commodore/VZ	Engine	V6																		V																								
Commodore/VZ	Engine	V6 Supercharged																																										
Commodore/VZ	Engine	V8 GEN III																		V																								
Commodore/VZ	Engine	V8 GEN IV																		V	V																							
Commodore/VZ	Transmission	A/T																																										
Commodore/VZ	Transmission	A/T GEN III																																										
Commodore/VZ	Chassis	ABS/TC/ESP8.0																																										
Commodore/VZ	Chassis	ABS/ETC																																										
Commodore/VZ	Body	SRS Airbag																																										
Commodore/VZ	Body	BCM(Body control module)																																										
Commodore/VZ	Body	PIM(Powertrain Interface Module)																																										
Commodore/VZ	Body	Instrument																																										
Commodore/VZ	Body	Audio System																																										
Commodore/VE	Engine	V6																																										
Commodore/VE	Engine	V8 GEN IV																		V	V																							
Commodore/VE	Transmission	A/T																																										
Commodore/VE	Chassis	EBCM(Electronic brake control module)																																										
Commodore/VE	Chassis	TPMS(Tyre pressure monitor system)																																										
Commodore/VE	Chassis	Fuel Pump Control																																										
Commodore/VE	Body	BCM(Body control module)																																										
Commodore/VE	Body	VTM(Theft deterrent module)																																										
Commodore/VE	Body	RFA(Remote function actuator)																																										
Commodore/VE	Body	SDM(SRS Airbag)																																										
Commodore/VE	Body	IPC(Instrument Panel Cluster)																																										
Commodore/VE	Body	HVAC(Heating Ventilating and Air Conditioning)																																										
Commodore/VE	Body	MSM																																										
Commodore/VE	Body	Parking Assist																																										
Commodore/VE	Body	AHL																																										
Commodore/VE	Infotainment System	Audio System																																										
Commodore/VE	Infotainment System	Rear Seat Entertainment																																										

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
VF Comodore	Powertrain	3.0L LFW(Beta)																																										
VF Comodore	Powertrain	3.6L LFX																																										
VF Comodore	Powertrain	6.2L LS3(Beta)																																										
VF Comodore	Powertrain	FICM(Fuel injector control module)																																										
VF Comodore	Powertrain	TCM(Transmission control unit)																																										
VF Comodore	Chassis	CCM(Chassis control module)																																										
VF Comodore	Chassis	EBCM(Electronic brake control module)																																										
VF Comodore	Chassis	PBCM(Parking brake control module)																																										
VF Comodore	Chassis	PSCM(Power steering control module)																																										
VF Comodore	Chassis	SWASM(Steering wheel angle sensor module)																																										
VF Comodore	Chassis	SCM(Suspension control module)																																										
VF Comodore	Body	Immobilizer																																										
VF Comodore	Body	BCM(Body control module)																																										
VF Comodore	Body	SDM(Inflatable restraint sensing and diagnostic module)																																										
VF Comodore	Body	IC(Instrument cluster)																																										
VF Comodore	Body	HDM(Head-up display module)																																										
VF Comodore	Body	RCP(Radio control panel)																																										
VF Comodore	Body	HVACCP(Heating Ventilating and Air Conditioning control panel)																																										
VF Comodore	Body	Radio																																										
VF Comodore	Body	HVAC(Heating Ventilating and Air Conditioning)																																										
VF Comodore	Body	RODCM(Right side object detection control module)																																										
VF Comodore	Body	LODCM(Left side object detection control module)																																										
VF Comodore	Body	Keyless																																										
VF Comodore	Body	PACM(Parking assist control module)																																										
VF Comodore	Body	FVCM(Front view camera module)																																										
VF Comodore	Body	SCCM(Steering column lock control module)																																										
YG Cruze		Engine																																										
YG Cruze		Transmission																																										
YG Cruze		ABS																																										
YG Cruze		EPS																																										
YG Cruze		Immobilizer																																										
YG Cruze		Airbag																																										
Cruze/Gasoline	Powertrain	Engine control module(1.4L LUJ)																																										
Cruze/Gasoline	Powertrain	Engine control module(1.8L 2H0)									V																																	
Cruze/Gasoline	Powertrain	Fuel pump control module																																										
Cruze/Gasoline	Powertrain	Transmission control module																																										
Cruze/Gasoline	Chassis	EBCM(Electronic brake control module)																																										
Cruze/Gasoline	Chassis	Multi-Axis acceleration sensor module																																										

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
Cruze/Gasoline	Chassis	Steering wheel angle sensor module																																									
Cruze/Gasoline	Chassis	Electrinic power steering control module																																									
Cruze/Gasoline	Body	Body control module																																									
Cruze/Gasoline	Body	Immobilizer																					V																				
Cruze/Gasoline	Body	SDM(Inflatable restraint sensing and diagnostic module)																																									
Cruze/Gasoline	Body	Passenger presence module																																									
Cruze/Gasoline	Body	Instrument panel cluster																				V																					
Cruze/Gasoline	Body	Auto Heating ventilating and air conditioning																																									
Cruze/Gasoline	Body	Manual Heating ventilating and air conditioning																																									
Cruze/Gasoline	Body	Front seat heating control module																																									
Cruze/Gasoline	Body	Park assist control module																																									
Cruze/Gasoline	Body	Passive entry passive start																																									
Cruze/Gasoline	Body	Steering column lock control module																																									
Cruze/Gasoline	Infotainment	Radio																																									
Cruze/Gasoline	Infotainment	Telematics communication interface control module																																									
Cruze/Diesel	Powertrain	Engine control module(2.0L LLW)																																									
Cruze/Diesel	Powertrain	Engine control module(2.0L LNP)																																									
Cruze/Diesel	Powertrain	Fuel pump control module																																									
Cruze/Diesel	Powertrain	Transmission control module																																									
Cruze/Diesel	Chassis	EBCM(Electronic brake control module)																																									
Cruze/Diesel	Chassis	Multi-Axis acceleration sensor module																																									
Cruze/Diesel	Chassis	Steering wheel angle sensor module																																									
Cruze/Diesel	Chassis	Electrinic power steering control module																																									
Cruze/Diesel	Body	Body control module																																									
Cruze/Diesel	Body	Immobilizer																					V																				
Cruze/Diesel	Body	SDM(Inflatable restraint sensing and diagnostic module)																																									
Cruze/Diesel	Body	Passenger presence module																																									
Cruze/Diesel	Body	Instrument panel cluster																				V																					
Cruze/Diesel	Body	Auto Heating ventilating and air conditioning																																									
Cruze/Diesel	Body	Manual Heating ventilating and air conditioning																																									
Cruze/Diesel	Body	Front seat heating control module																																									
Cruze/Diesel	Body	Park assist control module																																									
Cruze/Diesel	Body	Passive entry passive start																																									
Cruze/Diesel	Body	Steering column lock control module																																									
Cruze/Diesel	Infotainment	Radio																																									
Cruze/Diesel	Infotainment	Telematics communication interface control module																																									
Barina/Spark/Barina(T300)	Powertrain	Engine control module(1.4L LUJ)																																									
Barina/Spark/Barina(T300)	Powertrain	Engine control unit(1.6L LDE)																																									

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
Barina/Spark/Barina(T300)	Powertrain	TCM(Transmission control module)																																										
Barina/Spark/Barina(T300)	Chassis	Electronic brake control module																																										
Barina/Spark/Barina(T300)	Chassis	Multi-Axis acceleration sensor module																																										
Barina/Spark/Barina(T300)	Chassis	Steering wheel angle sensor module																																										
Barina/Spark/Barina(T300)	Body	Immobilizer																																										
Barina/Spark/Barina(T300)	Body	BCM(Body control module)																																										
Barina/Spark/Barina(T300)	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																										
Barina/Spark/Barina(T300)	Body	IPC(Instrument Cluster)																				V																						
Barina/Spark/Barina(T300)	Information	Radio																																										
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LEB)	V	V	V	V	V	V	V	V																																		
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LMT)									V																																	
Barina/Spark/Barina Spark	Powertrain	Engine LPG																																										
Barina/Spark/Barina Spark	Powertrain	TCM(Transmission control module)																																										
Barina/Spark/Barina Spark	Chassis	Electronic brake control module																																										
Barina/Spark/Barina Spark	Chassis	Multi-Axis acceleration sensor module																																										
Barina/Spark/Barina Spark	Chassis	Electronic power steering control module																																										
Barina/Spark/Barina Spark	Chassis	Steering wheel angle sensor module																																										
Barina/Spark/Barina Spark	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																				V		V				
Barina/Spark/Barina Spark	Body	IPC(Instrument Cluster)																																										
Barina/Spark/Barina Spark	Body	Keyless entry control module										V																																
Barina/Spark/Barina Spark	Body	Passenger presensce module											V																															
Barina/Spark/Barina(OPEL)	Engine	C 14 SE																																										
Barina/Spark/Barina(OPEL)	Engine	Z 14 XE														V	V		V																									
Barina/Spark/Barina(OPEL)	Engine	Z 14 XEP												V	V	V	V	V	V																									
Barina/Spark/Barina(OPEL)	Engine	Z 16 SE														V	V		V																									
Barina/Spark/Barina(OPEL)	Engine	Z 18 XE													V	V	V	V																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13/14/20																																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13II/20/22/30												V																														
Barina/Spark/Barina(OPEL)	Transmission	AF 13-II/17/20/22 CAN																																										
Barina/Spark/Barina(OPEL)	Chassis	ABS 5.3/5.4 +TC																																										
Barina/Spark/Barina(OPEL)	Chassis	ABS/ESP8																																										
Barina/Spark/Barina(OPEL)	Chassis	Electronic Power Steering																																										
Barina/Spark/Barina(OPEL)	Body	Immobiliser																																										
Barina/Spark/Barina(OPEL)	Body	Body Control Module																																										
Barina/Spark/Barina(OPEL)	Body	SRS Airbag																																										
Barina/Spark/Barina(OPEL)	Body	Instrument																																										
Barina/Spark/Barina(OPEL)	Information	Read security PIN code																																										
Barina/Spark/Barina(OPEL)	Information	Trip info display																																										

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.5 Sohc																							V			V															
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.6 Dohc																			V				V			V															
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	A/T Aisin5																																									
Barina/Spark/Barina(GM/DAEWOO)	Chassis	ABS																																									
Barina/Spark/Barina(GM/DAEWOO)	Body	Immobilizer																																									
Barina/Spark/Barina(GM/DAEWOO)	Body	Keyless entry																																									
Barina/Spark/Barina(GM/DAEWOO)	Body	Air Bag																																									
Volt		ECM(Engine control module)																																									
Volt		FPCM(Fuel pump control module)																																									
Volt		HVCM(Hybrid powertrain control module)																																									
Volt		HVCM2(Hybrid powertrain control module 2)																																									
Volt		TCM(Transmission control module)																																									
Volt		DMCM1(Driver motor control module 1)																																									
Volt		DMCM2(Driver motor control module 2)																																									
Volt		BCCM(Battery charger control module)																																									
Volt		BECM(Battery energy control module)																																									
Volt		ATFP(Auxiliary transmission fluid pump)																																									
Volt		EBCM(Electronic brake control module)																																									
Volt		PBCM(Parking brake control module)																																									
Volt		MAASM(Multi axis acceleration sensor module)																																									
Volt		PSCM(Power steering control module)																																									
Volt		SWASM(Steering wheel angle sensor module)																																									
Volt		Immobilizer																																									
Volt		BCM(Body control module)																																									
Volt		SDM(Inflatable restraint sensing and diagnostic module)																																									
Volt		IC(Instrument cluster)																																									
Volt		Radio																																									
Volt		TCIC(Telematics communication interface control module)																																									
Volt		HVAC(Heating Ventilating and Air Conditioning)																																									
Volt		CHCM(Coolant heater control module)																																									
Volt		SHCM(Seat heating control module)																																									
Volt		Keyless																																									
Volt		PACM(Parking assist control module)																																									
Volt		FVC(Front view camera)																																									
Volt		SCCM(Steering column lock control module)																																									
Captiva/Captiva	Powertrain	Engine Diesel																											V	V	V	V	V	V	V	V							
Captiva/Captiva	Powertrain	Engine 2.4 Dohc																																									
Captiva/Captiva	Powertrain	Engine 3.2 Dohc																																									

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
Captiva/Captiva	Powertrain	Auto Transmission												V																													
Captiva/Captiva	Chassis	EBCM(Electronic brake control module)																																									
Captiva/Captiva	Chassis	TCCM(Transfer case control module)																																									
Captiva/Captiva	Body	SDM(SRS Airbag)																																									
Captiva/Captiva	Body	IPC(Instrument panel cluster)																																									
Captiva/Captiva	Body	BCM(Body control module)																																									
Captiva/Captiva	Body	VTD(Theft deterrent module)																																									
Captiva/Captiva	Body	RFA(Remote function actuator)																																									
Captiva/Captiva 5/7	Powertrain	Engine control module(2.2L LNQ)																																									
Captiva/Captiva 5/7	Powertrain	Engine control module(2.4L LE5)																																									
Captiva/Captiva 5/7	Powertrain	Engine control module(3.0L LF1)																																									
Captiva/Captiva 5/7	Powertrain	Fuel pump control module																																									
Captiva/Captiva 5/7	Powertrain	Transmission control module																																									
Captiva/Captiva 5/7	Chassis	Electronic brake control module																																									
Captiva/Captiva 5/7	Chassis	Parking brake control module																																									
Captiva/Captiva 5/7	Chassis	Rear differential clutch control module																																									
Captiva/Captiva 5/7	Body	Body control module																																									
Captiva/Captiva 5/7	Body	Inflatable restraint sensing and diagnostic module																																									
Captiva/Captiva 5/7	Body	Instrument panel cluster																																									
Captiva/Captiva 5/7	Body	HVAC control module																																									
Captiva/Captiva 5/7	Body	Remote control door lock receiver																																									
Captiva/Captiva 5/7	Body	Theft deterrent module																																									
Captiva/Captiva 5/7	Body	Parking assist control module																																									
Captiva/Captiva 5/7	Infotainment	Radio																																									
VIVA		1.4/1.5 Dohc																							V	V	V																
VIVA		1.6 Dohc																			V				V	V	V																
VIVA		1.8 Dohc																			V				V			V															
VIVA		A/T																											V														
VIVA		ABS																																									
VIVA		SSPS																																									
VIVA		Immobilizer																																									
VIVA		Keyless entry																																									
VIVA		Air Bag																																									
Malibu		ECM 2.4L(Engine control module 2.4L LE9)																																									
Malibu		ECM 2.0L(Engine control module 2.0L LBS)		V	V	V	V		V	V																																	
Malibu		TCM(Transmission control module)																																									
Malibu		EBCM(Electronic brake control module)																																									
Malibu		MAASM(Multi axis acceleration sensor module)																																									

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
Malibu		PSCM(Power steering control module)																																									
Malibu		SWASM(Steering wheel angle sensor module)																																									
Malibu		Immobilizer																																									
Malibu		BCM(Body control module)																																									
Malibu		SDM(Inflatable restraint sensing and diagnostic module)																																									
Malibu		IC(Instrument cluster)																																									
Malibu		Radio																																									
Malibu		HVAC(Heating Ventilating and Air Conditioning)																																									
Malibu		Keyless																																									
Malibu		PACM(Parking assist control module)																																									
Malibu		SCCM(Steering column lock control module)																																									
Epica		2.0 Dohc(Beta)																							V																		
Epica		Engine Diesel																																V									
Epica		A/T Aisin5(Beta)												V																													
Epica		A/T GF 6												V																													
Epica		ABS																																									
Epica		SSPS																																									
Epica		SDM(SRS AIRBAG)																																									
Epica		Keyless entry																																									
Epica		ISU/BCM																																									
Astra/Astra-F	Engine	C16SE																																									
Astra/Astra-F	Engine	C18SEL																V																									
Astra/Astra-F	Transmission	AF 13/14/20																																									
Astra/Astra-F	Transmission	AF 13II/20/22/30												V																													
Astra/Astra-F	Body	Immobilizer																																									
Astra/Astra-F	Body	Airbag-S																																									
Astra/Astra-G	Engine	Z 18 XE													V	V	V	V																									
Astra/Astra-G	Engine	X 18 XE1																V																									
Astra/Astra-G	Engine	Z 22 SE														V			V		V																						
Astra/Astra-G	Transmission	AF 13-II/17/20/22																																									
Astra/Astra-G	Transmission	AF 13-II/17/20/22 CAN																																									
Astra/Astra-G	Chassis	ABS 5.3/5.4 +TC																																									
Astra/Astra-G	Chassis	ESP																																									
Astra/Astra-G	Chassis	Electronic Power Steering																																									
Astra/Astra-G	Body	Immobiliser																																									
Astra/Astra-G	Body	SRS Airbag																																									
Astra/Astra-G	Body	Instrument																																									
Astra/Astra-G	Body	Engine Cooling Module																																									

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
Astra/Astra-G	Body	Add On Heater																																									
Astra/Astra-G	Body	Electronic Climate Control																																									
Astra/Astra-G	Body	Central Door Lock																																									
Astra/Astra-G	Body	Softtop Controller																																									
Astra/Astra-G	Information	Read security PIN code																																									
Astra/Astra-G	Infortainment System	Trip Info Display																																									
Astra/Astra-G	Infortainment System	Multi Info Display																																									
Astra/Astra-H	Engine	Z 18 XE														V																											
Astra/Astra-H	Engine	Z 18 XER												V		V																											
Astra/Astra-H	Engine	Z 19 DT(Beta)																																									
Astra/Astra-H	Engine	Z 20 LEH																																									
Astra/Astra-H	Engine	Z 20 LER														V																											
Astra/Astra-H	Engine	Z 22 YH														V																											
Astra/Astra-H	Transmission	AF 40-6(Beta)												V																													
Astra/Astra-H	Transmission	AF 22-4												V																													
Astra/Astra-H	Transmission	AF 17-4												V																													
Astra/Astra-H	Chassis	ABS/TC/ESP																																									
Astra/Astra-H	Chassis	EHPS(Electrohydraulic power steering)																																									
Astra/Astra-H	Body	SDM(Airbag)																																									
Astra/Astra-H	Body	CIM(Steering column module)																																									
Astra/Astra-H	Body	IPC(Instrument control unit)																																									
Astra/Astra-H	Body	UEC(Underhood electrical centre)																																									
Astra/Astra-H	Body	REC(Rear electrical centre)																																									
Astra/Astra-H	Body	PAS(Park pilot)																																									
Astra/Astra-H	Body	SAC(Air conditioning)																																									
Astra/Astra-H	Body	Electrohydraulic hard top																																									
Combo/Corsa-B	Engine	C 14 SE																																									
Combo/Corsa-B	Engine	Z 14 XE														V	V		V																								
Combo/Corsa-B	Engine	Z 14 XEP												V	V	V	V	V	V																								
Combo/Corsa-B	Engine	Z 16 SE														V	V		V																								
Combo/Corsa-B	Engine	Z 18 XE													V	V	V	V																									
Combo/Corsa-B	Transmission	AF 13/14/20																																									
Combo/Corsa-B	Transmission	AF 13II/20/22/30												V																													
Combo/Corsa-B	Transmission	AF 13-II/17/20/22 CAN																																									
Combo/Corsa-B	Chassis	ABS 5.3/5.4 +TC																																									
Combo/Corsa-B	Chassis	ABS/ESP8																																									
Combo/Corsa-B	Chassis	Electronic Power Steering																																									
Combo/Corsa-B	Body	Immobiliser																																									

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
Combo/Corsa-B	Body	Body Control Module																																									
Combo/Corsa-B	Body	SRS Airbag																																									
Combo/Corsa-B	Body	Instrument																																									
Combo/Corsa-B	Information	Trip info display																																									
Combo/Corsa-C	Engine	Z 14 XE														V	V		V																								
Combo/Corsa-C	Engine	Z 14 XEP												V	V	V	V	V	V																								
Combo/Corsa-C	Engine	Z 16 SE														V	V		V																								
Combo/Corsa-C	Engine	Z 18 XE													V	V	V	V																									
Combo/Corsa-C	Transmission	AF 13-II/17/20/22 CAN																																									
Combo/Corsa-C	Chassis	ABS 5.3/5.4 +TC																																									
Combo/Corsa-C	Chassis	Electronic Power Steering																																									
Combo/Corsa-C	Body	Immobiliser																																									
Combo/Corsa-C	Body	Body Control Module																																									
Combo/Corsa-C	Body	SRS Airbag																																									
Combo/Corsa-C	Body	Instrument																																									
Combo/Corsa-C	Information	Read security PIN code																																									
Trax		Engine Control Module 1.4L - 2WD																																									
Trax		Engine Control Module 1.4L - AWD																																									
Trax		Engine Control Module 1.8L - 2WD																																									
Trax		Engine Control Module 1.8L - AWD																																									
Trax		Engine Control Module 1.7L		V																																							
Trax		Transmission																																									
Trax		Rear Differential Clutch Control Module - Beta																																									
Trax		EBCM(Electronic brake control module)																																									
Trax		PSCM(Power steering control module)																																									
Trax		SWASM(Steering wheel angle sensor module)																																									
Trax		Immobilizer																																									
Trax		BCM(Body control module)																																									
Trax		SDM(Inflatable restraint sensing and diagnostic module)																																									
Trax		IC(Instrument cluster)																																									
Trax		Radio																																									
Trax		HVAC(Heating Ventilating and Air Conditioning)																																									
Trax		SHCM(Seat heating control module)																																									
Trax		PACM(Parking assist control module)																																									
Jackaroo/Monterey	Engine	6VD1																						V																			
Jackaroo/Monterey	Engine	3.0 L4 4JX1																																									
Jackaroo/Monterey	Engine	3.2 V6 6VD1 Hitachi																																									
Jackaroo/Monterey	Engine	3.5 V6 6VE1 Hitachi																																									

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
Jackaroo/Monterey	Transmission	4L30E																																									
Jackaroo/Monterey	Transmission	AW30-40LE																																									
Jackaroo/Monterey	Body	Immobilizer																																									
Jackaroo/Monterey	Body	Airbag																																									
Jackaroo/Monterey	Body	Aniti theft warning																																									
Rodeo/Colorado/Rodeo	Engine	6VD1																						V																			
Rodeo/Colorado/Rodeo	Engine	2.2 L4 SOHC																																									
Rodeo/Colorado/Rodeo	Engine	2.X L4 HV240																																									
Rodeo/Colorado/Rodeo	Engine	3.2 V6 6VD1 Hitachi																																									
Rodeo/Colorado/Rodeo	Transmission	4L30E																																									
Rodeo/Colorado/Rodeo	Transmission	AW30-40LE																																									
Rodeo/Colorado/Rodeo	Body	Immobilizer																																									
Rodeo/Colorado/Rodeo	Body	Aniti theft warning																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.2 L4 SOHC																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.4 LP1 EURO3																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.X L4 HV240																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.0 iTD(4JH1-TC)																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.5 V6 6VE1 Hitachi																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	V6 Engine																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AT JR405E																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AW30-40LE																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	Auto transmission																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Chassis	ABS																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Immobilizer																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	PIM(Powertrain interface module)																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	SRS airbag																																									
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Aniti theft warning																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	2.4 LP1 EURO3																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Delphi)																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Transtron)																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	V6 Engine																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Chassis	ABS																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	AW30-40LE																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	Auto transmission																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Immobilizer(V6 Engine)																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	SRS(Airbag)																																									
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Aniti theft warning																																									
New Colorado/Colorado7	Engine	2.8L Diesel(LWH)																																									

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU4																																									
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU5																																									
New Colorado/Colorado7	Chassis	Electronic brake control module																																									
New Colorado/Colorado7	Chassis	Transfer case control module																																									
New Colorado/Colorado7	Chassis	Steering wheel angle sensor module																																									
New Colorado/Colorado7	Chassis	Multi-Axis acceleration sensor module																																									
New Colorado/Colorado7	Transmission	Auto transmission(6SP)																																									
New Colorado/Colorado7	Body	Immobilizer(New Colorado)																																									
New Colorado/Colorado7	Body	Body Control Module																																									
New Colorado/Colorado7	Body	Instrument cluster																				V																					
New Colorado/Colorado7	Body	SRS(Airbag)																																									
Tigra/Tigra-B	Engine	C 14 SE																																									
Tigra/Tigra-B	Engine	Z 14 XE														V	V		V																								
Tigra/Tigra-B	Engine	Z 14 XEP												V	V	V	V	V	V																								
Tigra/Tigra-B	Engine	Z 16 SE														V	V		V																								
Tigra/Tigra-B	Engine	Z 18 XE													V	V	V	V																									
Tigra/Tigra-B	Transmission	AF 13/14/20																																									
Tigra/Tigra-B	Transmission	AF 13II/20/22/30												V																													
Tigra/Tigra-B	Transmission	AF 13-II/17/20/22 CAN																																									
Tigra/Tigra-B	Chassis	ABS 5.3/5.4 +TC																																									
Tigra/Tigra-B	Chassis	ABS/ESP8																																									
Tigra/Tigra-B	Chassis	Electronic Power Steering																																									
Tigra/Tigra-B	Body	Immobiliser																																									
Tigra/Tigra-B	Body	Body Control Module																																									
Tigra/Tigra-B	Body	SRS Airbag																																									
Tigra/Tigra-B	Body	Instrument																																									
Tigra/Tigra-B	Information	Read security PIN code																																									
Tigra/Tigra-B	Information	Trip info display																																									
Vectra/Vectra-B	Engine	C 20 SEL																																									
Vectra/Vectra-B	Engine	C 22 SEL																V																									
Vectra/Vectra-B	Engine	Z 22 SE																																									
Vectra/Vectra-B	Engine	X 25 XE																																									
Vectra/Vectra-B	Engine	Y 26 SE																																									
Vectra/Vectra-B	Transmission	AF 13/14/20																																									
Vectra/Vectra-B	Transmission	AF 13II/20/22/30												V																													
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22																																									
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22 CAN																																									
Vectra/Vectra-B	Chassis	ABS 5.3/5.4 +TC																																									

Model	Group	System	APP Learn	Exhaust Gas Temperature Sensor Learn	MAF Sensor Learn	EGR Valve Learn	Fuel Rail Pressure Sensor or Fuel Rail Learn	Crankshaft Position Reluctor Wheel Learn	Turbocharger Learn	Flywheel Learn	Fuel Trim Reset	Add Replace Key Fobs	Passenger Presence Sensor Learn	Reset learned values	Program idle speed	Electronic throttle control	Injector cutoff test	RPM control	EGR control	Reset engine oil life	Learn crank angle sensing error	CAN Bus Configuration Learn	Key programming	Reset O2 BLM	CO Adjustment(Leaded Fuel Onley)	ECM Segment	VIN WRITE	TEC LEARN	AT(TCM) Learning Value Initialization	Idle Test	Fuel Correction Test	Service Regeneration	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	Vheicle Variant Coding	Field Service	New SDM Program	Adapt Reset	SDM Reset	Write VIN	SDM ID Input
Vectra/Vectra-B	Body	Immobiliser																																									
Vectra/Vectra-B	Body	SRS Airbag SAB6																																									
Vectra/Vectra-B	Body	Central Door Lock																																									
Vectra/Vectra-B	Body	Instrument																																									
Vectra/Vectra-B	Information	Read security PIN code																																									
Vectra/Vectra-B	Infotainment System	Trip info display																																									
Vectra/Vectra-C	Engine	Z 32 SE																																									
Vectra/Vectra-C	Transmission	AF 23-5/33-5/40-6												V																													
Vectra/Vectra-C	Chassis	ABS/TC/ESP																																									
Vectra/Vectra-C	Chassis	EHPS(Electrohydraulic power steering)																																									
Vectra/Vectra-C	Body	SDM(Airbag)																																									
Vectra/Vectra-C	Body	CIM(Steering column module)																																									
Vectra/Vectra-C	Body	BCM(Body control module)																																									
Vectra/Vectra-C	Body	IPC(Instrument control unit)																																									
Vectra/Vectra-C	Body	REC(Rear electrical control)																																									
Vectra/Vectra-C	Body	UEC(Underhood electrical control)																																									
Vectra/Vectra-C	Body	DDM(Driver door module)																																									
Vectra/Vectra-C	Body	PDM(Passenger door module)																																									
Vectra/Vectra-C	Body	SLM(Shift lever module)																																									
Vectra/Vectra-C	Body	Electronic seat																																									
Vectra/Vectra-C	Information	Read security PIN code																																									
Zafira/2001-2005	Engine	Z 22 SE														V			V		V																						
Zafira/2001-2005	Transmission	AF 13-II/17/20/22 CAN																																									
Zafira/2001-2005	Chassis	ABS 5.3/5.4 +TC																																									
Zafira/2001-2005	Chassis	Electronic Power Steering																																									
Zafira/2001-2005	Body	Immobiliser																																									
Zafira/2001-2005	Body	SRS Airbag																																									
Zafira/2001-2005	Body	Instrument																																									
Zafira/2001-2005	Body	Engine Cooling Module																																									
Zafira/2001-2005	Body	Central Door Lock																																									
Zafira/2001-2005	Information	Read security PIN code																																									
Zafira/2001-2005	Infortainment System	Trip Info Display																																									

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
Commodore/VR	Engine	V6/V8																																									
Commodore/VR	Transmission	A/T																																									
Commodore/VR	Chassis	ABS																																									
Commodore/VR	Body	SRS Airbag																																									
Commodore/VR	Body	BCM(Body control module)																																									
Commodore/VR	Body	TDM																																									
Commodore/VS	Engine	V6																																									
Commodore/VS	Engine	V8																																									
Commodore/VS	Transmission	V6 A/T																																									
Commodore/VS	Transmission	V8 A/T																																									
Commodore/VS	Chassis	ABS																																									
Commodore/VS	Body	SRS Airbag																																									
Commodore/VS	Body	BCM(Body control module)																																									
Commodore/VT(Include VSv8)	Engine	V6																																									
Commodore/VT(Include VSv8)	Engine	V8																																									
Commodore/VT(Include VSv8)	Engine	V8 GEN III																																									
Commodore/VT(Include VSv8)	Transmission	A/T																																									
Commodore/VT(Include VSv8)	Transmission	A/T GEN III																																									
Commodore/VT(Include VSv8)	Chassis	ABS																																									
Commodore/VT(Include VSv8)	Body	SRS Airbag																																									
Commodore/VT(Include VSv8)	Body	BCM(Body control module)																																									
Commodore/VT(Include VSv8)	Body	Instrument																																									
Commodore/VT(Include VSv8)	Body	PIM(Powertrain Interface Module)																																									
Commodore/VT(Include VSv8)	Body	Climate Control																																									
Commodore/VX	Engine	V6																																									
Commodore/VX	Engine	V6 Supercharged																																									
Commodore/VX	Engine	V8 GEN III																																									
Commodore/VX	Transmission	A/T																																									
Commodore/VX	Transmission	A/T GEN III																																									
Commodore/VX	Chassis	ABS																																									
Commodore/VX	Body	SRS Airbag																																									
Commodore/VX	Body	BCM(Body control module)																																									
Commodore/VX	Body	Instrument																																									
Commodore/VX	Body	PIM(Powertrain Interface Module)																																									
Commodore/VX	Body	Climate Control																																									
Commodore/VY	Engine	V6																																									
Commodore/VY	Engine	V6 Supercharged																																									
Commodore/VY	Engine	V8 GEN III																																									

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
Commodore/VY	Transmission	A/T																																									
Commodore/VY	Transmission	A/T GEN III																																									
Commodore/VY	Chassis	ABS																																									
Commodore/VY	Body	SRS Airbag																																									
Commodore/VY	Body	BCM(Body control module)																																									
Commodore/VY	Body	Instrument																																									
Commodore/VY	Body	PIM(Powertrain Interface Module)																																									
Commodore/VY	Body	Audio System																																									
Commodore/VZ	Engine	V6																					V																				
Commodore/VZ	Engine	V6 Supercharged																																									
Commodore/VZ	Engine	V8 GEN III																																									
Commodore/VZ	Engine	V8 GEN IV																																									
Commodore/VZ	Transmission	A/T																																									
Commodore/VZ	Transmission	A/T GEN III																																									
Commodore/VZ	Chassis	ABS/TC/ESP8.0																																									V
Commodore/VZ	Chassis	ABS/ETC																																									
Commodore/VZ	Body	SRS Airbag																																									
Commodore/VZ	Body	BCM(Body control module)																																									
Commodore/VZ	Body	PIM(Powertrain Interface Module)																																									
Commodore/VZ	Body	Instrument																																									
Commodore/VZ	Body	Audio System																																									
Commodore/VE	Engine	V6																																									
Commodore/VE	Engine	V8 GEN IV																					V																				
Commodore/VE	Transmission	A/T																																									
Commodore/VE	Chassis	EBCM(Electronic brake control module)																																									
Commodore/VE	Chassis	TPMS(Tyre pressure monitor system)																																									
Commodore/VE	Chassis	Fuel Pump Control																																									
Commodore/VE	Body	BCM(Body control module)																																									
Commodore/VE	Body	VTM(Theft deterrent module)																																									
Commodore/VE	Body	RFA(Remote function actuator)																																									
Commodore/VE	Body	SDM(SRS Airbag)																																									
Commodore/VE	Body	IPC(Instrument Panel Cluster)																																									
Commodore/VE	Body	HVAC(Heating Ventilating and Air Conditioning)																																									
Commodore/VE	Body	MSM																																									
Commodore/VE	Body	Parking Assist																																									
Commodore/VE	Body	AHL																																									
Commodore/VE	Infotainment System	Audio System																																									
Commodore/VE	Infotainment System	Rear Seat Entertainment																																									

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
VF Comodore	Powertrain	3.0L LFW(Beta)																																									
VF Comodore	Powertrain	3.6L LFX																																									
VF Comodore	Powertrain	6.2L LS3(Beta)																																									
VF Comodore	Powertrain	FICM(Fuel injector control module)																																									
VF Comodore	Powertrain	TCM(Transmission control unit)																																									
VF Comodore	Chassis	CCM(Chassis control module)																																									
VF Comodore	Chassis	EBCM(Electronic brake control module)																																									
VF Comodore	Chassis	PBCM(Parking brake control module)																																									
VF Comodore	Chassis	PSCM(Power steering control module)																																									
VF Comodore	Chassis	SWASM(Steering wheel angle sensor module)																																									
VF Comodore	Chassis	SCM(Suspension control module)																																									
VF Comodore	Body	Immobilizer																																									
VF Comodore	Body	BCM(Body control module)																																									
VF Comodore	Body	SDM(Inflatable restraint sensing and diagnostic module)																																									
VF Comodore	Body	IC(Instrument cluster)																																									
VF Comodore	Body	HDM(Head-up display module)																																									
VF Comodore	Body	RCP(Radio control panel)																																									
VF Comodore	Body	HVACCP(Heating Ventilating and Air Conditioning control panel)																																									
VF Comodore	Body	Radio																																									
VF Comodore	Body	HVAC(Heating Ventilating and Air Conditioning)																																									
VF Comodore	Body	RODCM(Right side object detection control module)																																									
VF Comodore	Body	LODCM(Left side object detection control module)																																									
VF Comodore	Body	Keyless																																									
VF Comodore	Body	PACM(Parking assist control module)																																									
VF Comodore	Body	FVCM(Front view camera module)																																									
VF Comodore	Body	SCCM(Steering column lock control module)																																									
YG Cruze		Engine																																									
YG Cruze		Transmission																																									
YG Cruze		ABS																																									
YG Cruze		EPS																																									
YG Cruze		Immobilizer																																									
YG Cruze		Airbag																																									
Cruze/Gasoline	Powertrain	Engine control module(1.4L LUJ)																																									
Cruze/Gasoline	Powertrain	Engine control module(1.8L 2H0)																																									
Cruze/Gasoline	Powertrain	Fuel pump control module																																									
Cruze/Gasoline	Powertrain	Transmission control module											V	V	V	V																											
Cruze/Gasoline	Chassis	EBCM(Electronic brake control module)																																									
Cruze/Gasoline	Chassis	Multi-Axis acceleration sensor module																																									

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
Cruze/Gasoline	Chassis	Steering wheel angle sensor module																																										
Cruze/Gasoline	Chassis	Electrinic power steering control module																																										
Cruze/Gasoline	Body	Body control module																																										
Cruze/Gasoline	Body	Immobilizer																																										
Cruze/Gasoline	Body	SDM(Inflatable restraint sensing and diagnostic module)																																										
Cruze/Gasoline	Body	Passenger presence module																																										
Cruze/Gasoline	Body	Instrument panel cluster																																										
Cruze/Gasoline	Body	Auto Heating ventilating and air conditioning																																										
Cruze/Gasoline	Body	Manual Heating ventilating and air conditioning																	V																									
Cruze/Gasoline	Body	Front seat heating control module																																										
Cruze/Gasoline	Body	Park assist control module																																										
Cruze/Gasoline	Body	Passive entry passive start																																										
Cruze/Gasoline	Body	Steering column lock control module																																										
Cruze/Gasoline	Infotainment	Radio																																										
Cruze/Gasoline	Infotainment	Telematics communication interface control module																																										
Cruze/Diesel	Powertrain	Engine control module(2.0L LLW)						V	V	V	V	V																																
Cruze/Diesel	Powertrain	Engine control module(2.0L LNP)																																										
Cruze/Diesel	Powertrain	Fuel pump control module																																										
Cruze/Diesel	Powertrain	Transmission control module											V	V	V	V																												
Cruze/Diesel	Chassis	EBCM(Electronic brake control module)																																										
Cruze/Diesel	Chassis	Multi-Axis acceleration sensor module																																										
Cruze/Diesel	Chassis	Steering wheel angle sensor module																																										
Cruze/Diesel	Chassis	Electrinic power steering control module																																										
Cruze/Diesel	Body	Body control module																																										
Cruze/Diesel	Body	Immobilizer																																										
Cruze/Diesel	Body	SDM(Inflatable restraint sensing and diagnostic module)																																										
Cruze/Diesel	Body	Passenger presence module																																										
Cruze/Diesel	Body	Instrument panel cluster																																										
Cruze/Diesel	Body	Auto Heating ventilating and air conditioning																																										
Cruze/Diesel	Body	Manual Heating ventilating and air conditioning																	V																									
Cruze/Diesel	Body	Front seat heating control module																																										
Cruze/Diesel	Body	Park assist control module																																										
Cruze/Diesel	Body	Passive entry passive start																																										
Cruze/Diesel	Body	Steering column lock control module																																										
Cruze/Diesel	Infotainment	Radio																																										
Cruze/Diesel	Infotainment	Telematics communication interface control module																																										
Barina/Spark/Barina(T300)	Powertrain	Engine control module(1.4L LUJ)																																										
Barina/Spark/Barina(T300)	Powertrain	Engine control unit(1.6L LDE)																																										

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
Barina/Spark/Barina(T300)	Powertrain	TCM(Transmission control module)																																										
Barina/Spark/Barina(T300)	Chassis	Electronic brake control module																																										
Barina/Spark/Barina(T300)	Chassis	Multi-Axis acceleration sensor module																																										
Barina/Spark/Barina(T300)	Chassis	Steering wheel angle sensor module																																										
Barina/Spark/Barina(T300)	Body	Immobilizer																																										
Barina/Spark/Barina(T300)	Body	BCM(Body control module)																																										
Barina/Spark/Barina(T300)	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																										
Barina/Spark/Barina(T300)	Body	IPC(Instrument Cluster)																																										
Barina/Spark/Barina(T300)	Information	Radio																																										
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LEB)																																										
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LMT)																																										
Barina/Spark/Barina Spark	Powertrain	Engine LPG																																										
Barina/Spark/Barina Spark	Powertrain	TCM(Transmission control module)																																										
Barina/Spark/Barina Spark	Chassis	Electronic brake control module																																										
Barina/Spark/Barina Spark	Chassis	Multi-Axis acceleration sensor module																																										
Barina/Spark/Barina Spark	Chassis	Electronic power steering control module																																										
Barina/Spark/Barina Spark	Chassis	Steering wheel angle sensor module																																										
Barina/Spark/Barina Spark	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																										
Barina/Spark/Barina Spark	Body	IPC(Instrument Cluster)					V																																					
Barina/Spark/Barina Spark	Body	Keyless entry control module																																										
Barina/Spark/Barina Spark	Body	Passenger presensce module																																										
Barina/Spark/Barina(OPEL)	Engine	C 14 SE																																										
Barina/Spark/Barina(OPEL)	Engine	Z 14 XE																																										
Barina/Spark/Barina(OPEL)	Engine	Z 14 XEP																																										
Barina/Spark/Barina(OPEL)	Engine	Z 16 SE																																										
Barina/Spark/Barina(OPEL)	Engine	Z 18 XE																																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13/14/20																																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13II/20/22/30																																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13-II/17/20/22 CAN																																										
Barina/Spark/Barina(OPEL)	Chassis	ABS 5.3/5.4 +TC																																										
Barina/Spark/Barina(OPEL)	Chassis	ABS/ESP8																																										
Barina/Spark/Barina(OPEL)	Chassis	Electronic Power Steering																																										
Barina/Spark/Barina(OPEL)	Body	Immobiliser																																										
Barina/Spark/Barina(OPEL)	Body	Body Control Module																																										
Barina/Spark/Barina(OPEL)	Body	SRS Airbag																																										
Barina/Spark/Barina(OPEL)	Body	Instrument																																										
Barina/Spark/Barina(OPEL)	Information	Read security PIN code																																										
Barina/Spark/Barina(OPEL)	Information	Trip info display																																										

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.5 Sohc																																									
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.6 Dohc															V	V																									
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	A/T Aisin5																						V																			
Barina/Spark/Barina(GM/DAEWOO)	Chassis	ABS																																									V
Barina/Spark/Barina(GM/DAEWOO)	Body	Immobilizer																																									
Barina/Spark/Barina(GM/DAEWOO)	Body	Keyless entry																																									
Barina/Spark/Barina(GM/DAEWOO)	Body	Air Bag																																									
Volt		ECM(Engine control module)																																									
Volt		FPCM(Fuel pump control module)																																									
Volt		HVCM(Hybrid powertrain control module)																																									
Volt		HVCM2(Hybrid powertrain control module 2)																																									
Volt		TCM(Transmission control module)																																									
Volt		DMCM1(Driver motor control module 1)																																									
Volt		DMCM2(Driver motor control module 2)																																									
Volt		BCCM(Battery charger control module)																																									
Volt		BECM(Battery energy control module)																																									
Volt		ATFP(Auxiliary transmission fluid pump)																																									
Volt		EBCM(Electronic brake control module)																																									
Volt		PBCM(Parking brake control module)																																									
Volt		MAASM(Multi axis acceleration sensor module)																																									
Volt		PSCM(Power steering control module)																																									
Volt		SWASM(Steering wheel angle sensor module)																																									
Volt		Immobilizer																																									
Volt		BCM(Body control module)																																									
Volt		SDM(Inflatable restraint sensing and diagnostic module)																																									
Volt		IC(Instrument cluster)																																									
Volt		Radio																																									
Volt		TCIC(Telematics communication interface control module)																																									
Volt		HVAC(Heating Ventilating and Air Conditioning)																																									
Volt		CHCM(Coolant heater control module)																																									
Volt		SHCM(Seat heating control module)																																									
Volt		Keyless																																									
Volt		PACM(Parking assist control module)																																									
Volt		FVC(Front view camera)																																									
Volt		SCCM(Steering column lock control module)																																									
Captiva/Captiva	Powertrain	Engine Diesel																																									
Captiva/Captiva	Powertrain	Engine 2.4 Dohc																											V	V													
Captiva/Captiva	Powertrain	Engine 3.2 Dohc																					V																				

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
Captiva/Captiva	Powertrain	Auto Transmission																						V																			
Captiva/Captiva	Chassis	EBCM(Electronic brake control module)																										V															V
Captiva/Captiva	Chassis	TCCM(Transfer case control module)																																									
Captiva/Captiva	Body	SDM(SRS Airbag)																																									
Captiva/Captiva	Body	IPC(Instrument panel cluster)																																									
Captiva/Captiva	Body	BCM(Body control module)																																									
Captiva/Captiva	Body	VTD(Theft deterrent module)																																									
Captiva/Captiva	Body	RFA(Remote function actuator)																																									
Captiva/Captiva 5/7	Powertrain	Engine control module(2.2L LNQ)																																									
Captiva/Captiva 5/7	Powertrain	Engine control module(2.4L LE5)																																									
Captiva/Captiva 5/7	Powertrain	Engine control module(3.0L LF1)																																									
Captiva/Captiva 5/7	Powertrain	Fuel pump control module																																									
Captiva/Captiva 5/7	Powertrain	Transmission control module																																									
Captiva/Captiva 5/7	Chassis	Electronic brake control module																																									
Captiva/Captiva 5/7	Chassis	Parking brake control module																																									
Captiva/Captiva 5/7	Chassis	Rear differential clutch control module																																									
Captiva/Captiva 5/7	Body	Body control module																																									
Captiva/Captiva 5/7	Body	Inflatable restraint sensing and diagnostic module																																									
Captiva/Captiva 5/7	Body	Instrument panel cluster																																									
Captiva/Captiva 5/7	Body	HVAC control module																																									
Captiva/Captiva 5/7	Body	Remote control door lock receiver																																									
Captiva/Captiva 5/7	Body	Theft deterrent module																																									
Captiva/Captiva 5/7	Body	Parking assist control module																																									
Captiva/Captiva 5/7	Infotainment	Radio																																									
VIVA		1.4/1.5 Dohc																						V	V																		
VIVA		1.6 Dohc																						V	V																		
VIVA		1.8 Dohc															V	V						V	V																		
VIVA		A/T																																									
VIVA		ABS																																									V
VIVA		SSPS																																									
VIVA		Immobilizer																																									
VIVA		Keyless entry																																									
VIVA		Air Bag																																									
Malibu		ECM 2.4L(Engine control module 2.4L LE9)																																									
Malibu		ECM 2.0L(Engine control module 2.0L LBS)						V																																			
Malibu		TCM(Transmission control module)																																									
Malibu		EBCM(Electronic brake control module)																																									
Malibu		MAASM(Multi axis acceleration sensor module)																																									

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
Malibu		PSCM(Power steering control module)																																									
Malibu		SWASM(Steering wheel angle sensor module)																																									
Malibu		Immobilizer																																									
Malibu		BCM(Body control module)																																									
Malibu		SDM(Inflatable restraint sensing and diagnostic module)																																									
Malibu		IC(Instrument cluster)																																									
Malibu		Radio																																									
Malibu		HVAC(Heating Ventilating and Air Conditioning)																																									
Malibu		Keyless																																									
Malibu		PACM(Parking assist control module)																																									
Malibu		SCCM(Steering column lock control module)																																									
Epica		2.0 Dohc(Beta)																						V	V																		
Epica		Engine Diesel																																									
Epica		A/T Aisin5(Beta)																						V																			
Epica		A/T GF 6													V	V								V		V	V																
Epica		ABS																						V				V															V
Epica		SSPS																																									
Epica		SDM(SRS AIRBAG)																																									
Epica		Keyless entry																																									
Epica		ISU/BCM																																									
Astra/Astra-F	Engine	C16SE																																									
Astra/Astra-F	Engine	C18SEL																																									
Astra/Astra-F	Transmission	AF 13/14/20																																									
Astra/Astra-F	Transmission	AF 13II/20/22/30																																									
Astra/Astra-F	Body	Immobilizer																																									
Astra/Astra-F	Body	Airbag-S																																									
Astra/Astra-G	Engine	Z 18 XE																																									
Astra/Astra-G	Engine	X 18 XE1																																									
Astra/Astra-G	Engine	Z 22 SE																																									
Astra/Astra-G	Transmission	AF 13-II/17/20/22																																									
Astra/Astra-G	Transmission	AF 13-II/17/20/22 CAN																																									
Astra/Astra-G	Chassis	ABS 5.3/5.4 +TC																																									
Astra/Astra-G	Chassis	ESP																																									
Astra/Astra-G	Chassis	Electronic Power Steering																																									
Astra/Astra-G	Body	Immobiliser																																									
Astra/Astra-G	Body	SRS Airbag																																									
Astra/Astra-G	Body	Instrument																																									
Astra/Astra-G	Body	Engine Cooling Module																																									

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
Astra/Astra-G	Body	Add On Heater																																									
Astra/Astra-G	Body	Electronic Climate Control																																									
Astra/Astra-G	Body	Central Door Lock																																									
Astra/Astra-G	Body	Softtop Controller																																									
Astra/Astra-G	Information	Read security PIN code																																									
Astra/Astra-G	Infortainment System	Trip Info Display																																									
Astra/Astra-G	Infortainment System	Multi Info Display																																									
Astra/Astra-H	Engine	Z 18 XE																																									
Astra/Astra-H	Engine	Z 18 XER																																									
Astra/Astra-H	Engine	Z 19 DT(Beta)																																									
Astra/Astra-H	Engine	Z 20 LEH																																									
Astra/Astra-H	Engine	Z 20 LER																																									
Astra/Astra-H	Engine	Z 22 YH																																									
Astra/Astra-H	Transmission	AF 40-6(Beta)																																									
Astra/Astra-H	Transmission	AF 22-4																																									
Astra/Astra-H	Transmission	AF 17-4																																									
Astra/Astra-H	Chassis	ABS/TC/ESP																																									
Astra/Astra-H	Chassis	EHPS(Electrohydraulic power steering)																																									
Astra/Astra-H	Body	SDM(Airbag)																																									
Astra/Astra-H	Body	CIM(Steering column module)																																									
Astra/Astra-H	Body	IPC(Instrument control unit)																																									
Astra/Astra-H	Body	UEC(Underhood electrical centre)																																									
Astra/Astra-H	Body	REC(Rear electrical centre)																																									
Astra/Astra-H	Body	PAS(Park pilot)																																									
Astra/Astra-H	Body	SAC(Air conditioning)																																									
Astra/Astra-H	Body	Electrohydraulic hard top																																									
Combo/Corsa-B	Engine	C 14 SE																																									
Combo/Corsa-B	Engine	Z 14 XE																																									
Combo/Corsa-B	Engine	Z 14 XEP																																									
Combo/Corsa-B	Engine	Z 16 SE																																									
Combo/Corsa-B	Engine	Z 18 XE																																									
Combo/Corsa-B	Transmission	AF 13/14/20																																									
Combo/Corsa-B	Transmission	AF 13II/20/22/30																																									
Combo/Corsa-B	Transmission	AF 13-II/17/20/22 CAN																																									
Combo/Corsa-B	Chassis	ABS 5.3/5.4 +TC																																									
Combo/Corsa-B	Chassis	ABS/ESP8																																									
Combo/Corsa-B	Chassis	Electronic Power Steering																																									
Combo/Corsa-B	Body	Immobiliser																																									

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
Combo/Corsa-B	Body	Body Control Module																																										
Combo/Corsa-B	Body	SRS Airbag																																										
Combo/Corsa-B	Body	Instrument																																										
Combo/Corsa-B	Information	Trip info display																																										
Combo/Corsa-C	Engine	Z 14 XE																																										
Combo/Corsa-C	Engine	Z 14 XEP																																										
Combo/Corsa-C	Engine	Z 16 SE																																										
Combo/Corsa-C	Engine	Z 18 XE																																										
Combo/Corsa-C	Transmission	AF 13-II/17/20/22 CAN																																										
Combo/Corsa-C	Chassis	ABS 5.3/5.4 +TC																																										
Combo/Corsa-C	Chassis	Electronic Power Steering																																										
Combo/Corsa-C	Body	Immobiliser																																										
Combo/Corsa-C	Body	Body Control Module																																										
Combo/Corsa-C	Body	SRS Airbag																																										
Combo/Corsa-C	Body	Instrument																																										
Combo/Corsa-C	Information	Read security PIN code																																										
Trax		Engine Control Module 1.4L - 2WD																																										
Trax		Engine Control Module 1.4L - AWD																																										
Trax		Engine Control Module 1.8L - 2WD																																										
Trax		Engine Control Module 1.8L - AWD																																										
Trax		Engine Control Module 1.7L																																										
Trax		Transmission																																										
Trax		Rear Differential Clutch Control Module - Beta																																										
Trax		EBCM(Electronic brake control module)																																										
Trax		PSCM(Power steering control module)																																										
Trax		SWASM(Steering wheel angle sensor module)																																										
Trax		Immobilizer																																										
Trax		BCM(Body control module)																																										
Trax		SDM(Inflatable restraint sensing and diagnostic module)																																										
Trax		IC(Instrument cluster)																																										
Trax		Radio																																										
Trax		HVAC(Heating Ventilating and Air Conditioning)																																										
Trax		SHCM(Seat heating control module)																																										
Trax		PACM(Parking assist control module)																																										
Jackaroo/Monterey	Engine	6VD1																																										
Jackaroo/Monterey	Engine	3.0 L4 4JX1																																										
Jackaroo/Monterey	Engine	3.2 V6 6VD1 Hitachi																																										
Jackaroo/Monterey	Engine	3.5 V6 6VE1 Hitachi																																										

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
Jackaroo/Monterey	Transmission	4L30E																																										
Jackaroo/Monterey	Transmission	AW30-40LE																																										
Jackaroo/Monterey	Body	Immobilizer																																										
Jackaroo/Monterey	Body	Airbag																																										
Jackaroo/Monterey	Body	Aniti theft warning																																										
Rodeo/Colorado/Rodeo	Engine	6VD1																																										
Rodeo/Colorado/Rodeo	Engine	2.2 L4 SOHC																																										
Rodeo/Colorado/Rodeo	Engine	2.X L4 HV240																																										
Rodeo/Colorado/Rodeo	Engine	3.2 V6 6VD1 Hitachi																																										
Rodeo/Colorado/Rodeo	Transmission	4L30E																																										
Rodeo/Colorado/Rodeo	Transmission	AW30-40LE																																										
Rodeo/Colorado/Rodeo	Body	Immobilizer																																										
Rodeo/Colorado/Rodeo	Body	Aniti theft warning																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.2 L4 SOHC																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.4 LP1 EURO3																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.X L4 HV240																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.0 iTD(4JH1-TC)																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.5 V6 6VE1 Hitachi																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	V6 Engine																					V																					
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AT JR405E																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AW30-40LE																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	Auto transmission																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Chassis	ABS																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Immobilizer																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	PIM(Powertrain interface module)																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	SRS airbag																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Aniti theft warning																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	2.4 LP1 EURO3																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Delphi)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Transtron)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	V6 Engine																					V																					
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Chassis	ABS																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	AW30-40LE																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	Auto transmission																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Immobilizer(V6 Engine)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	SRS(Airbag)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Aniti theft warning																																										
New Colorado/Colorado7	Engine	2.8L Diesel(LWH)							V	V																																		

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU4						V	V	V																																		
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU5						V	V	V																																		
New Colorado/Colorado7	Chassis	Electronic brake control module																																										
New Colorado/Colorado7	Chassis	Transfer case control module																																										
New Colorado/Colorado7	Chassis	Steering wheel angle sensor module																																										
New Colorado/Colorado7	Chassis	Multi-Axis acceleration sensor module																																										
New Colorado/Colorado7	Transmission	Auto transmission(6SP)																																										
New Colorado/Colorado7	Body	Immobilizer(New Colorado)																																										
New Colorado/Colorado7	Body	Body Control Module																																										
New Colorado/Colorado7	Body	Instrument cluster																																										
New Colorado/Colorado7	Body	SRS(Airbag)																																										
Tigra/Tigra-B	Engine	C 14 SE																																										
Tigra/Tigra-B	Engine	Z 14 XE																																										
Tigra/Tigra-B	Engine	Z 14 XEP																																										
Tigra/Tigra-B	Engine	Z 16 SE																																										
Tigra/Tigra-B	Engine	Z 18 XE																																										
Tigra/Tigra-B	Transmission	AF 13/14/20																																										
Tigra/Tigra-B	Transmission	AF 13II/20/22/30																																										
Tigra/Tigra-B	Transmission	AF 13-II/17/20/22 CAN																																										
Tigra/Tigra-B	Chassis	ABS 5.3/5.4 +TC																																										
Tigra/Tigra-B	Chassis	ABS/ESP8																																										
Tigra/Tigra-B	Chassis	Electronic Power Steering																																										
Tigra/Tigra-B	Body	Immobiliser																																										
Tigra/Tigra-B	Body	Body Control Module																																										
Tigra/Tigra-B	Body	SRS Airbag																																										
Tigra/Tigra-B	Body	Instrument																																										
Tigra/Tigra-B	Information	Read security PIN code																																										
Tigra/Tigra-B	Information	Trip info display																																										
Vectra/Vectra-B	Engine	C 20 SEL																																										
Vectra/Vectra-B	Engine	C 22 SEL																																										
Vectra/Vectra-B	Engine	Z 22 SE																																										
Vectra/Vectra-B	Engine	X 25 XE																																										
Vectra/Vectra-B	Engine	Y 26 SE																																										
Vectra/Vectra-B	Transmission	AF 13/14/20																																										
Vectra/Vectra-B	Transmission	AF 13II/20/22/30																																										
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22																																										
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22 CAN																																										
Vectra/Vectra-B	Chassis	ABS 5.3/5.4 +TC																																										

Model	Group	System	Brake Adapt	Fuel Efficiency Check-Mode (While inspecting)	Fuel Efficiency Driving Mode (After inspecting)	Write VIN_BCM	Odd Meter Reset	DPF Pressure sensor learn	Fuel injector learn	Fuel rail(pressure sensor) learn	DPF Reset	EGR Cooler run time counter reset	Clutch Fast Learn	Solenoid cleaning	Reset TCM Adaption Value	VIN Write	Learn crank angle sensing error(TEC learning)	Reset long term fuel trim	HVAC Actuator learn	DTC Erase	CO Adjust for Open-Loop (Temporary)	CO Adjust for Open-Loop (Store)	Throttle body relearn	Actuators Test	EVAP Leak Test	Service cleaning procedure	Fast learn adapt process	Streering Wheel Angle Reset	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel correction Test	Replay DPF	ECM Immobilizer Learning	TCC SOLENOID CONTROL	PCS CURRENT CONTROL	SHIFT GEAR CONTROL	Manual Control	Gear Tension	MOTOR HOME POSITION	Motor Home Position	Hydraulic Control	TCS Hydraulic Control	Air Bleeding
Vectra/Vectra-B	Body	Immobiliser																																									
Vectra/Vectra-B	Body	SRS Airbag SAB6																																									
Vectra/Vectra-B	Body	Central Door Lock																																									
Vectra/Vectra-B	Body	Instrument																																									
Vectra/Vectra-B	Information	Read security PIN code																																									
Vectra/Vectra-B	Infotainment System	Trip info display																																									
Vectra/Vectra-C	Engine	Z 32 SE																																									
Vectra/Vectra-C	Transmission	AF 23-5/33-5/40-6																																									
Vectra/Vectra-C	Chassis	ABS/TC/ESP																																									
Vectra/Vectra-C	Chassis	EHPS(Electrohydraulic power steering)																																									
Vectra/Vectra-C	Body	SDM(Airbag)																																									
Vectra/Vectra-C	Body	CIM(Steering column module)																																									
Vectra/Vectra-C	Body	BCM(Body control module)																																									
Vectra/Vectra-C	Body	IPC(Instrument control unit)																																									
Vectra/Vectra-C	Body	REC(Rear electrical control)																																									
Vectra/Vectra-C	Body	UEC(Underhood electrical control)																																									
Vectra/Vectra-C	Body	DDM(Driver door module)																																									
Vectra/Vectra-C	Body	PDM(Passenger door module)																																									
Vectra/Vectra-C	Body	SLM(Shift lever module)																																									
Vectra/Vectra-C	Body	Electronic seat																																									
Vectra/Vectra-C	Information	Read security PIN code																																									
Zafira/2001-2005	Engine	Z 22 SE																																									
Zafira/2001-2005	Transmission	AF 13-II/17/20/22 CAN																																									
Zafira/2001-2005	Chassis	ABS 5.3/5.4 +TC																																									
Zafira/2001-2005	Chassis	Electronic Power Steering																																									
Zafira/2001-2005	Body	Immobiliser																																									
Zafira/2001-2005	Body	SRS Airbag																																									
Zafira/2001-2005	Body	Instrument																																									
Zafira/2001-2005	Body	Engine Cooling Module																																									
Zafira/2001-2005	Body	Central Door Lock																																									
Zafira/2001-2005	Information	Read security PIN code																																									
Zafira/2001-2005	Infortainment System	Trip Info Display																																									

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
Commodore/VR	Engine	V6/V8																																										
Commodore/VR	Transmission	A/T																																										
Commodore/VR	Chassis	ABS																																										
Commodore/VR	Body	SRS Airbag																																										
Commodore/VR	Body	BCM(Body control module)																																										
Commodore/VR	Body	TDM										V	V																															
Commodore/VS	Engine	V6																																										
Commodore/VS	Engine	V8																																										
Commodore/VS	Transmission	V6 A/T																																										
Commodore/VS	Transmission	V8 A/T																																										
Commodore/VS	Chassis	ABS																																										
Commodore/VS	Body	SRS Airbag																																										
Commodore/VS	Body	BCM(Body control module)										V	V	V	V	V																												
Commodore/VT(Include VSv8)	Engine	V6																V																										
Commodore/VT(Include VSv8)	Engine	V8																																										
Commodore/VT(Include VSv8)	Engine	V8 GEN III															V																											
Commodore/VT(Include VSv8)	Transmission	A/T																																										
Commodore/VT(Include VSv8)	Transmission	A/T GEN III																																										
Commodore/VT(Include VSv8)	Chassis	ABS																	V	V																								
Commodore/VT(Include VSv8)	Body	SRS Airbag																																										
Commodore/VT(Include VSv8)	Body	BCM(Body control module)																			V																							
Commodore/VT(Include VSv8)	Body	Instrument																				V	V	V																				
Commodore/VT(Include VSv8)	Body	PIM(Powertrain Interface Module)																																										
Commodore/VT(Include VSv8)	Body	Climate Control																																										
Commodore/VX	Engine	V6																							V																			
Commodore/VX	Engine	V6 Supercharged																V																										
Commodore/VX	Engine	V8 GEN III															V																											
Commodore/VX	Transmission	A/T																																										
Commodore/VX	Transmission	A/T GEN III																																										
Commodore/VX	Chassis	ABS																	V	V																								
Commodore/VX	Body	SRS Airbag																																										
Commodore/VX	Body	BCM(Body control module)																			V																							
Commodore/VX	Body	Instrument																				V	V	V																				
Commodore/VX	Body	PIM(Powertrain Interface Module)																																										
Commodore/VX	Body	Climate Control																																										
Commodore/VY	Engine	V6																							V																			
Commodore/VY	Engine	V6 Supercharged																V																										
Commodore/VY	Engine	V8 GEN III															V																											

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
Commodore/VY	Transmission	A/T																																										
Commodore/VY	Transmission	A/T GEN III																																										
Commodore/VY	Chassis	ABS																	V	V												V												
Commodore/VY	Body	SRS Airbag																																										
Commodore/VY	Body	BCM(Body control module)																								V																		
Commodore/VY	Body	Instrument																						V			V	V	V	V														
Commodore/VY	Body	PIM(Powertrain Interface Module)																																			V							
Commodore/VY	Body	Audio System																																										
Commodore/VZ	Engine	V6																													V													
Commodore/VZ	Engine	V6 Supercharged																V																										
Commodore/VZ	Engine	V8 GEN III															V																											
Commodore/VZ	Engine	V8 GEN IV																																										
Commodore/VZ	Transmission	A/T																																							V			
Commodore/VZ	Transmission	A/T GEN III																																										
Commodore/VZ	Chassis	ABS/TC/ESP8.0																															V											
Commodore/VZ	Chassis	ABS/ETC																	V	V												V												
Commodore/VZ	Body	SRS Airbag																																										
Commodore/VZ	Body	BCM(Body control module)																								V								V	V	V								
Commodore/VZ	Body	PIM(Powertrain Interface Module)																													V						V	V						
Commodore/VZ	Body	Instrument																						V			V												V	V				
Commodore/VZ	Body	Audio System																																										
Commodore/VE	Engine	V6																																								V	V	
Commodore/VE	Engine	V8 GEN IV																																										
Commodore/VE	Transmission	A/T																																							V			
Commodore/VE	Chassis	EBCM(Electronic brake control module)																	V																									
Commodore/VE	Chassis	TPMS(Tyre pressure monitor system)																																										
Commodore/VE	Chassis	Fuel Pump Control																																										
Commodore/VE	Body	BCM(Body control module)																																										
Commodore/VE	Body	VTM(Theft deterrent module)																																										
Commodore/VE	Body	RFA(Remote function actuator)																																										
Commodore/VE	Body	SDM(SRS Airbag)																																										
Commodore/VE	Body	IPC(Instrument Panel Cluster)																																										
Commodore/VE	Body	HVAC(Heating Ventilating and Air Conditioning)																																										
Commodore/VE	Body	MSM																																										
Commodore/VE	Body	Parking Assist																																										
Commodore/VE	Body	AHL																																										
Commodore/VE	Infotainment System	Audio System																																										
Commodore/VE	Infotainment System	Rear Seat Entertainment																																										

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
VF Comodore	Powertrain	3.0L LFW(Beta)																																										
VF Comodore	Powertrain	3.6L LFX																																										
VF Comodore	Powertrain	6.2L LS3(Beta)																																										
VF Comodore	Powertrain	FICM(Fuel injector control module)																																										
VF Comodore	Powertrain	TCM(Transmission control unit)																																										
VF Comodore	Chassis	CCM(Chassis control module)																																										
VF Comodore	Chassis	EBCM(Electronic brake control module)																																										
VF Comodore	Chassis	PBCM(Parking brake control module)																																										
VF Comodore	Chassis	PSCM(Power steering control module)																																										
VF Comodore	Chassis	SWASM(Steering wheel angle sensor module)																																										
VF Comodore	Chassis	SCM(Suspension control module)																																										
VF Comodore	Body	Immobilizer																																										
VF Comodore	Body	BCM(Body control module)																																										
VF Comodore	Body	SDM(Inflatable restraint sensing and diagnostic module)																																										
VF Comodore	Body	IC(Instrument cluster)																																										
VF Comodore	Body	HDM(Head-up display module)																																										
VF Comodore	Body	RCP(Radio control panel)																																										
VF Comodore	Body	HVACCP(Heating Ventilating and Air Conditioning control panel)																																										
VF Comodore	Body	Radio																																										
VF Comodore	Body	HVAC(Heating Ventilating and Air Conditioning)																																										
VF Comodore	Body	RODCM(Right side object detection control module)																																										
VF Comodore	Body	LODCM(Left side object detection control module)																																										
VF Comodore	Body	Keyless																																										
VF Comodore	Body	PACM(Parking assist control module)																																										
VF Comodore	Body	FVCM(Front view camera module)																																										
VF Comodore	Body	SCCM(Steering column lock control module)																																										
YG Cruze		Engine																																										
YG Cruze		Transmission																																										
YG Cruze		ABS																																										
YG Cruze		EPS																																										
YG Cruze		Immobilizer																																										
YG Cruze		Airbag																																										
Cruze/Gasoline	Powertrain	Engine control module(1.4L LUJ)																																										
Cruze/Gasoline	Powertrain	Engine control module(1.8L 2H0)																																										
Cruze/Gasoline	Powertrain	Fuel pump control module																																										
Cruze/Gasoline	Powertrain	Transmission control module																																										
Cruze/Gasoline	Chassis	EBCM(Electronic brake control module)																																										
Cruze/Gasoline	Chassis	Multi-Axis acceleration sensor module																																										

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
Cruze/Gasoline	Chassis	Steering wheel angle sensor module																																										
Cruze/Gasoline	Chassis	Electrinic power steering control module																																										
Cruze/Gasoline	Body	Body control module																																										
Cruze/Gasoline	Body	Immobilizer																																										
Cruze/Gasoline	Body	SDM(Inflatable restraint sensing and diagnostic module)																																										
Cruze/Gasoline	Body	Passenger presence module																																										
Cruze/Gasoline	Body	Instrument panel cluster																																										
Cruze/Gasoline	Body	Auto Heating ventilating and air conditioning																																										
Cruze/Gasoline	Body	Manual Heating ventilating and air conditioning																																										
Cruze/Gasoline	Body	Front seat heating control module																																										
Cruze/Gasoline	Body	Park assist control module																																										
Cruze/Gasoline	Body	Passive entry passive start																																										
Cruze/Gasoline	Body	Steering column lock control module																																										
Cruze/Gasoline	Infotainment	Radio																																										
Cruze/Gasoline	Infotainment	Telematics communication interface control module																																										
Cruze/Diesel	Powertrain	Engine control module(2.0L LLW)																																										
Cruze/Diesel	Powertrain	Engine control module(2.0L LNP)																																										
Cruze/Diesel	Powertrain	Fuel pump control module																																										
Cruze/Diesel	Powertrain	Transmission control module																																										
Cruze/Diesel	Chassis	EBCM(Electronic brake control module)																																										
Cruze/Diesel	Chassis	Multi-Axis acceleration sensor module																																										
Cruze/Diesel	Chassis	Steering wheel angle sensor module																																										
Cruze/Diesel	Chassis	Electrinic power steering control module																																										
Cruze/Diesel	Body	Body control module																																										
Cruze/Diesel	Body	Immobilizer																																										
Cruze/Diesel	Body	SDM(Inflatable restraint sensing and diagnostic module)																																										
Cruze/Diesel	Body	Passenger presence module																																										
Cruze/Diesel	Body	Instrument panel cluster																																										
Cruze/Diesel	Body	Auto Heating ventilating and air conditioning																																										
Cruze/Diesel	Body	Manual Heating ventilating and air conditioning																																										
Cruze/Diesel	Body	Front seat heating control module																																										
Cruze/Diesel	Body	Park assist control module																																										
Cruze/Diesel	Body	Passive entry passive start																																										
Cruze/Diesel	Body	Steering column lock control module																																										
Cruze/Diesel	Infotainment	Radio																																										
Cruze/Diesel	Infotainment	Telematics communication interface control module																																										
Barina/Spark/Barina(T300)	Powertrain	Engine control module(1.4L LUJ)																																										
Barina/Spark/Barina(T300)	Powertrain	Engine control unit(1.6L LDE)																																										

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
Barina/Spark/Barina(T300)	Powertrain	TCM(Transmission control module)																																										
Barina/Spark/Barina(T300)	Chassis	Electronic brake control module																																										
Barina/Spark/Barina(T300)	Chassis	Multi-Axis acceleration sensor module																																										
Barina/Spark/Barina(T300)	Chassis	Steering wheel angle sensor module																																										
Barina/Spark/Barina(T300)	Body	Immobilizer																																										
Barina/Spark/Barina(T300)	Body	BCM(Body control module)																																										
Barina/Spark/Barina(T300)	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																										
Barina/Spark/Barina(T300)	Body	IPC(Instrument Cluster)																																										
Barina/Spark/Barina(T300)	Information	Radio																																										
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LEB)																																										
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LMT)																																										
Barina/Spark/Barina Spark	Powertrain	Engine LPG																																										
Barina/Spark/Barina Spark	Powertrain	TCM(Transmission control module)																																										
Barina/Spark/Barina Spark	Chassis	Electronic brake control module																																										
Barina/Spark/Barina Spark	Chassis	Multi-Axis acceleration sensor module																																										
Barina/Spark/Barina Spark	Chassis	Electronic power steering control module																																										
Barina/Spark/Barina Spark	Chassis	Steering wheel angle sensor module																																										
Barina/Spark/Barina Spark	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																										
Barina/Spark/Barina Spark	Body	IPC(Instrument Cluster)																																										
Barina/Spark/Barina Spark	Body	Keyless entry control module																																										
Barina/Spark/Barina Spark	Body	Passenger presensce module																																										
Barina/Spark/Barina(OPEL)	Engine	C 14 SE																																										
Barina/Spark/Barina(OPEL)	Engine	Z 14 XE																																										
Barina/Spark/Barina(OPEL)	Engine	Z 14 XEP																																										
Barina/Spark/Barina(OPEL)	Engine	Z 16 SE																																										
Barina/Spark/Barina(OPEL)	Engine	Z 18 XE																																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13/14/20																																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13II/20/22/30																																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13-II/17/20/22 CAN																																										
Barina/Spark/Barina(OPEL)	Chassis	ABS 5.3/5.4 +TC																																										
Barina/Spark/Barina(OPEL)	Chassis	ABS/ESP8																																										
Barina/Spark/Barina(OPEL)	Chassis	Electronic Power Steering																																										
Barina/Spark/Barina(OPEL)	Body	Immobiliser																																										
Barina/Spark/Barina(OPEL)	Body	Body Control Module																																										
Barina/Spark/Barina(OPEL)	Body	SRS Airbag																																										
Barina/Spark/Barina(OPEL)	Body	Instrument																																										
Barina/Spark/Barina(OPEL)	Information	Read security PIN code																																										
Barina/Spark/Barina(OPEL)	Information	Trip info display																																										

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.5 Sohc																																										
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.6 Dohc																																										
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	A/T Aisin5																																										
Barina/Spark/Barina(GM/DAEWOO)	Chassis	ABS		V	V																																							
Barina/Spark/Barina(GM/DAEWOO)	Body	Immobilizer																																										
Barina/Spark/Barina(GM/DAEWOO)	Body	Keyless entry																																										
Barina/Spark/Barina(GM/DAEWOO)	Body	Air Bag						V	V																																			
Volt		ECM(Engine control module)																																										
Volt		FPCM(Fuel pump control module)																																										
Volt		HVCM(Hybrid powertrain control module)																																										
Volt		HVCM2(Hybrid powertrain control module 2)																																										
Volt		TCM(Transmission control module)																																										
Volt		DMCM1(Driver motor control module 1)																																										
Volt		DMCM2(Driver motor control module 2)																																										
Volt		BCCM(Battery charger control module)																																										
Volt		BECM(Battery energy control module)																																										
Volt		ATFP(Auxiliary transmission fluid pump)																																										
Volt		EBCM(Electronic brake control module)																																										
Volt		PBCM(Parking brake control module)																																										
Volt		MAASM(Multi axis acceleration sensor module)																																										
Volt		PSCM(Power steering control module)																																										
Volt		SWASM(Steering wheel angle sensor module)																																										
Volt		Immobilizer																																										
Volt		BCM(Body control module)																																										
Volt		SDM(Inflatable restraint sensing and diagnostic module)																																										
Volt		IC(Instrument cluster)																																										
Volt		Radio																																										
Volt		TCIC(Telematics communication interface control module)																																										
Volt		HVAC(Heating Ventilating and Air Conditioning)																																										
Volt		CHCM(Coolant heater control module)																																										
Volt		SHCM(Seat heating control module)																																										
Volt		Keyless																																										
Volt		PACM(Parking assist control module)																																										
Volt		FVC(Front view camera)																																										
Volt		SCCM(Steering column lock control module)																																										
Captiva/Captiva	Powertrain	Engine Diesel																																										
Captiva/Captiva	Powertrain	Engine 2.4 Dohc																																										
Captiva/Captiva	Powertrain	Engine 3.2 Dohc																																										

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
Captiva/Captiva	Powertrain	Auto Transmission																																										
Captiva/Captiva	Chassis	EBCM(Electronic brake control module)				V																																						
Captiva/Captiva	Chassis	TCCM(Transfer case control module)																																										
Captiva/Captiva	Body	SDM(SRS Airbag)																																										
Captiva/Captiva	Body	IPC(Instrument panel cluster)																																										
Captiva/Captiva	Body	BCM(Body control module)																																										
Captiva/Captiva	Body	VTD(Theft deterrent module)																																										
Captiva/Captiva	Body	RFA(Remote function actuator)																																										
Captiva/Captiva 5/7	Powertrain	Engine control module(2.2L LNQ)																																										
Captiva/Captiva 5/7	Powertrain	Engine control module(2.4L LE5)																																										
Captiva/Captiva 5/7	Powertrain	Engine control module(3.0L LF1)																																										
Captiva/Captiva 5/7	Powertrain	Fuel pump control module																																										
Captiva/Captiva 5/7	Powertrain	Transmission control module																																										
Captiva/Captiva 5/7	Chassis	Electronic brake control module																																										
Captiva/Captiva 5/7	Chassis	Parking brake control module																																										
Captiva/Captiva 5/7	Chassis	Rear differential clutch control module																																										
Captiva/Captiva 5/7	Body	Body control module																																										
Captiva/Captiva 5/7	Body	Inflatable restraint sensing and diagnostic module																																										
Captiva/Captiva 5/7	Body	Instrument panel cluster																																										
Captiva/Captiva 5/7	Body	HVAC control module																																										
Captiva/Captiva 5/7	Body	Remote control door lock receiver																																										
Captiva/Captiva 5/7	Body	Theft deterrent module																																										
Captiva/Captiva 5/7	Body	Parking assist control module																																										
Captiva/Captiva 5/7	Infotainment	Radio																																										
VIVA		1.4/1.5 Dohc																																										
VIVA		1.6 Dohc																																										
VIVA		1.8 Dohc																																										
VIVA		A/T																																										
VIVA		ABS			V																																							
VIVA		SSPS																																										
VIVA		Immobilizer																																										
VIVA		Keyless entry																																										
VIVA		Air Bag						V	V																																			
Malibu		ECM 2.4L(Engine control module 2.4L LE9)																																										
Malibu		ECM 2.0L(Engine control module 2.0L LBS)																																										
Malibu		TCM(Transmission control module)																																										
Malibu		EBCM(Electronic brake control module)																																										
Malibu		MAASM(Multi axis acceleration sensor module)																																										

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
Malibu		PSCM(Power steering control module)																																										
Malibu		SWASM(Steering wheel angle sensor module)																																										
Malibu		Immobilizer																																										
Malibu		BCM(Body control module)																																										
Malibu		SDM(Inflatable restraint sensing and diagnostic module)																																										
Malibu		IC(Instrument cluster)																																										
Malibu		Radio																																										
Malibu		HVAC(Heating Ventilating and Air Conditioning)																																										
Malibu		Keyless																																										
Malibu		PACM(Parking assist control module)																																										
Malibu		SCCM(Steering column lock control module)																																										
Epica		2.0 Dohc(Beta)																																										
Epica		Engine Diesel																																										
Epica		A/T Aisin5(Beta)																																										
Epica		A/T GF 6																																										
Epica		ABS			V																																							
Epica		SSPS																																										
Epica		SDM(SRS AIRBAG)																																										
Epica		Keyless entry																																										
Epica		ISU/BCM								V																																		
Astra/Astra-F	Engine	C16SE																																										
Astra/Astra-F	Engine	C18SEL																																										
Astra/Astra-F	Transmission	AF 13/14/20																																										
Astra/Astra-F	Transmission	AF 13II/20/22/30																																										
Astra/Astra-F	Body	Immobilizer																																										
Astra/Astra-F	Body	Airbag-S																																										
Astra/Astra-G	Engine	Z 18 XE																																										
Astra/Astra-G	Engine	X 18 XE1																																										
Astra/Astra-G	Engine	Z 22 SE																																										
Astra/Astra-G	Transmission	AF 13-II/17/20/22																																										
Astra/Astra-G	Transmission	AF 13-II/17/20/22 CAN																																										
Astra/Astra-G	Chassis	ABS 5.3/5.4 +TC																																										
Astra/Astra-G	Chassis	ESP				V																																						
Astra/Astra-G	Chassis	Electronic Power Steering																																										
Astra/Astra-G	Body	Immobiliser																																										
Astra/Astra-G	Body	SRS Airbag																																										
Astra/Astra-G	Body	Instrument																																										
Astra/Astra-G	Body	Engine Cooling Module																																										

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
Astra/Astra-G	Body	Add On Heater																																										
Astra/Astra-G	Body	Electronic Climate Control																																										
Astra/Astra-G	Body	Central Door Lock																																										
Astra/Astra-G	Body	Softtop Controller																																										
Astra/Astra-G	Information	Read security PIN code																																										
Astra/Astra-G	Infortainment System	Trip Info Display																																										
Astra/Astra-G	Infortainment System	Multi Info Display																																										
Astra/Astra-H	Engine	Z 18 XE																																										
Astra/Astra-H	Engine	Z 18 XER																																										
Astra/Astra-H	Engine	Z 19 DT(Beta)																																										
Astra/Astra-H	Engine	Z 20 LEH																																										
Astra/Astra-H	Engine	Z 20 LER																																										
Astra/Astra-H	Engine	Z 22 YH																																										
Astra/Astra-H	Transmission	AF 40-6(Beta)																																										
Astra/Astra-H	Transmission	AF 22-4																																										
Astra/Astra-H	Transmission	AF 17-4																																										
Astra/Astra-H	Chassis	ABS/TC/ESP																																										
Astra/Astra-H	Chassis	EHPS(Electrohydraulic power steering)																																										
Astra/Astra-H	Body	SDM(Airbag)																																										
Astra/Astra-H	Body	CIM(Steering column module)				V																																						
Astra/Astra-H	Body	IPC(Instrument control unit)																																										
Astra/Astra-H	Body	UEC(Underhood electrical centre)																																										
Astra/Astra-H	Body	REC(Rear electrical centre)																																										
Astra/Astra-H	Body	PAS(Park pilot)																																										
Astra/Astra-H	Body	SAC(Air conditioning)																																										
Astra/Astra-H	Body	Electrohydraulic hard top																																										
Combo/Corsa-B	Engine	C 14 SE																																										
Combo/Corsa-B	Engine	Z 14 XE																																										
Combo/Corsa-B	Engine	Z 14 XEP																																										
Combo/Corsa-B	Engine	Z 16 SE																																										
Combo/Corsa-B	Engine	Z 18 XE																																										
Combo/Corsa-B	Transmission	AF 13/14/20																																										
Combo/Corsa-B	Transmission	AF 13II/20/22/30																																										
Combo/Corsa-B	Transmission	AF 13-II/17/20/22 CAN																																										
Combo/Corsa-B	Chassis	ABS 5.3/5.4 +TC																																										
Combo/Corsa-B	Chassis	ABS/ESP8																																										
Combo/Corsa-B	Chassis	Electronic Power Steering																																										
Combo/Corsa-B	Body	Immobiliser																																										

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
Combo/Corsa-B	Body	Body Control Module																																										
Combo/Corsa-B	Body	SRS Airbag																																										
Combo/Corsa-B	Body	Instrument																																										
Combo/Corsa-B	Information	Trip info display																																										
Combo/Corsa-C	Engine	Z 14 XE																																										
Combo/Corsa-C	Engine	Z 14 XEP																																										
Combo/Corsa-C	Engine	Z 16 SE																																										
Combo/Corsa-C	Engine	Z 18 XE																																										
Combo/Corsa-C	Transmission	AF 13-II/17/20/22 CAN																																										
Combo/Corsa-C	Chassis	ABS 5.3/5.4 +TC																																										
Combo/Corsa-C	Chassis	Electronic Power Steering																																										
Combo/Corsa-C	Body	Immobiliser																																										
Combo/Corsa-C	Body	Body Control Module																																										
Combo/Corsa-C	Body	SRS Airbag																																										
Combo/Corsa-C	Body	Instrument																																										
Combo/Corsa-C	Information	Read security PIN code																																										
Trax		Engine Control Module 1.4L - 2WD																																										
Trax		Engine Control Module 1.4L - AWD																																										
Trax		Engine Control Module 1.8L - 2WD																																										
Trax		Engine Control Module 1.8L - AWD																																										
Trax		Engine Control Module 1.7L																																										
Trax		Transmission																																										
Trax		Rear Differential Clutch Control Module - Beta																																										
Trax		EBCM(Electronic brake control module)																																										
Trax		PSCM(Power steering control module)																																										
Trax		SWASM(Steering wheel angle sensor module)																																										
Trax		Immobilizer																																										
Trax		BCM(Body control module)																																										
Trax		SDM(Inflatable restraint sensing and diagnostic module)																																										
Trax		IC(Instrument cluster)																																										
Trax		Radio																																										
Trax		HVAC(Heating Ventilating and Air Conditioning)																																										
Trax		SHCM(Seat heating control module)																																										
Trax		PACM(Parking assist control module)																																										
Jackaroo/Monterey	Engine	6VD1																																										
Jackaroo/Monterey	Engine	3.0 L4 4JX1																																										
Jackaroo/Monterey	Engine	3.2 V6 6VD1 Hitachi																																										
Jackaroo/Monterey	Engine	3.5 V6 6VE1 Hitachi																																										

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
Jackaroo/Monterey	Transmission	4L30E																																										
Jackaroo/Monterey	Transmission	AW30-40LE																																										
Jackaroo/Monterey	Body	Immobilizer																																										
Jackaroo/Monterey	Body	Airbag																																										
Jackaroo/Monterey	Body	Aniti theft warning																																										
Rodeo/Colorado/Rodeo	Engine	6VD1																																										
Rodeo/Colorado/Rodeo	Engine	2.2 L4 SOHC																																										
Rodeo/Colorado/Rodeo	Engine	2.X L4 HV240																																										
Rodeo/Colorado/Rodeo	Engine	3.2 V6 6VD1 Hitachi																																										
Rodeo/Colorado/Rodeo	Transmission	4L30E																																										
Rodeo/Colorado/Rodeo	Transmission	AW30-40LE																																										
Rodeo/Colorado/Rodeo	Body	Immobilizer																																										
Rodeo/Colorado/Rodeo	Body	Aniti theft warning																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.2 L4 SOHC																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.4 LP1 EURO3																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.X L4 HV240																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.0 iTD(4JH1-TC)																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.5 V6 6VE1 Hitachi																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	V6 Engine																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AT JR405E																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AW30-40LE																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	Auto transmission																																							V			
Rodeo/Colorado/RA Rodeo(Up to 2007)	Chassis	ABS																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Immobilizer																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	PIM(Powertrain interface module)																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	SRS airbag																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Aniti theft warning																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	2.4 LP1 EURO3																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Delphi)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Transtron)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	V6 Engine																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Chassis	ABS																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	AW30-40LE																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	Auto transmission																																							V			
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Immobilizer(V6 Engine)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	SRS(Airbag)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Aniti theft warning																																										
New Colorado/Colorado7	Engine	2.8L Diesel(LWH)																																										

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU4																																										
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU5																																										
New Colorado/Colorado7	Chassis	Electronic brake control module																																										
New Colorado/Colorado7	Chassis	Transfer case control module																																										
New Colorado/Colorado7	Chassis	Steering wheel angle sensor module																																										
New Colorado/Colorado7	Chassis	Multi-Axis acceleration sensor module																																										
New Colorado/Colorado7	Transmission	Auto transmission(6SP)																																										
New Colorado/Colorado7	Body	Immobilizer(New Colorado)																																										
New Colorado/Colorado7	Body	Body Control Module																																										
New Colorado/Colorado7	Body	Instrument cluster																																										
New Colorado/Colorado7	Body	SRS(Airbag)																																										
Tigra/Tigra-B	Engine	C 14 SE																																										
Tigra/Tigra-B	Engine	Z 14 XE																																										
Tigra/Tigra-B	Engine	Z 14 XEP																																										
Tigra/Tigra-B	Engine	Z 16 SE																																										
Tigra/Tigra-B	Engine	Z 18 XE																																										
Tigra/Tigra-B	Transmission	AF 13/14/20																																										
Tigra/Tigra-B	Transmission	AF 13II/20/22/30																																										
Tigra/Tigra-B	Transmission	AF 13-II/17/20/22 CAN																																										
Tigra/Tigra-B	Chassis	ABS 5.3/5.4 +TC																																										
Tigra/Tigra-B	Chassis	ABS/ESP8																																										
Tigra/Tigra-B	Chassis	Electronic Power Steering																																										
Tigra/Tigra-B	Body	Immobiliser																																										
Tigra/Tigra-B	Body	Body Control Module																																										
Tigra/Tigra-B	Body	SRS Airbag																																										
Tigra/Tigra-B	Body	Instrument																																										
Tigra/Tigra-B	Information	Read security PIN code																																										
Tigra/Tigra-B	Information	Trip info display																																										
Vectra/Vectra-B	Engine	C 20 SEL																																										
Vectra/Vectra-B	Engine	C 22 SEL																																										
Vectra/Vectra-B	Engine	Z 22 SE																																										
Vectra/Vectra-B	Engine	X 25 XE																																										
Vectra/Vectra-B	Engine	Y 26 SE																																										
Vectra/Vectra-B	Transmission	AF 13/14/20																																										
Vectra/Vectra-B	Transmission	AF 13II/20/22/30																																										
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22																																										
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22 CAN																																										
Vectra/Vectra-B	Chassis	ABS 5.3/5.4 +TC																																										

Model	Group	System	ABS Bleed	EBCM Type	EBCM Air Bleeding	Steering angle sensor calibration	Trouble Continue Time	Driver SBR Control	Passenger SBR Control	Program Transponder(2.0 Diesel)	ISU Key Coding	Extra Remote Key	All New Key	Commodore VS BCM Security Information and Program	Commodore VS BCM Extra Remote Key	Commodore VS BCM All New Key	ECM install	VT_Power Balance	Brake Bleed	ABS_Auto Test	Battery saver shut down time	INSTRUMENT Configuration	Commodore Instrument Fuel Gauge Calibration	Reset Service Interval	VX_Power Balance	Program Remote Key	V8 Configuration	Configuration V6 / V6 SC	Configuration V6 LPG	Configuration V8 AWD	PIM link to ECM	VT_ABS_Auto Test	Calibrate steering angle sensor	BCM User Setting	BCM Option	BCM Install	PIM Configuration	Program VIN	V6 Configuration	Reset Trip Comput	TAP CELLS RESET	ECM Reset	FUEL TRIM RESET
Vectra/Vectra-B	Body	Immobiliser																																										
Vectra/Vectra-B	Body	SRS Airbag SAB6																																										
Vectra/Vectra-B	Body	Central Door Lock																																										
Vectra/Vectra-B	Body	Instrument																																										
Vectra/Vectra-B	Information	Read security PIN code																																										
Vectra/Vectra-B	Infotainment System	Trip info display																																										
Vectra/Vectra-C	Engine	Z 32 SE																																										
Vectra/Vectra-C	Transmission	AF 23-5/33-5/40-6																																										
Vectra/Vectra-C	Chassis	ABS/TC/ESP																																										
Vectra/Vectra-C	Chassis	EHPS(Electrohydraulic power steering)																																										
Vectra/Vectra-C	Body	SDM(Airbag)																																										
Vectra/Vectra-C	Body	CIM(Steering column module)				V																																						
Vectra/Vectra-C	Body	BCM(Body control module)																																										
Vectra/Vectra-C	Body	IPC(Instrument control unit)																																										
Vectra/Vectra-C	Body	REC(Rear electrical control)																																										
Vectra/Vectra-C	Body	UEC(Underhood electrical control)																																										
Vectra/Vectra-C	Body	DDM(Driver door module)																																										
Vectra/Vectra-C	Body	PDM(Passenger door module)																																										
Vectra/Vectra-C	Body	SLM(Shift lever module)																																										
Vectra/Vectra-C	Body	Electronic seat																																										
Vectra/Vectra-C	Information	Read security PIN code																																										
Zafira/2001-2005	Engine	Z 22 SE																																										
Zafira/2001-2005	Transmission	AF 13-II/17/20/22 CAN																																										
Zafira/2001-2005	Chassis	ABS 5.3/5.4 +TC																																										
Zafira/2001-2005	Chassis	Electronic Power Steering																																										
Zafira/2001-2005	Body	Immobiliser																																										
Zafira/2001-2005	Body	SRS Airbag																																										
Zafira/2001-2005	Body	Instrument																																										
Zafira/2001-2005	Body	Engine Cooling Module																																										
Zafira/2001-2005	Body	Central Door Lock																																										
Zafira/2001-2005	Information	Read security PIN code																																										
Zafira/2001-2005	Infortainment System	Trip Info Display																																										

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
Commodore/VR	Engine	V6/V8																																										
Commodore/VR	Transmission	A/T																																										
Commodore/VR	Chassis	ABS																																										
Commodore/VR	Body	SRS Airbag																																										
Commodore/VR	Body	BCM(Body control module)																																										
Commodore/VR	Body	TDM																																										
Commodore/VS	Engine	V6																																										
Commodore/VS	Engine	V8																																										
Commodore/VS	Transmission	V6 A/T																																										
Commodore/VS	Transmission	V8 A/T																																										
Commodore/VS	Chassis	ABS																																										
Commodore/VS	Body	SRS Airbag																																										
Commodore/VS	Body	BCM(Body control module)																																										
Commodore/VT(Include VSv8)	Engine	V6																																										
Commodore/VT(Include VSv8)	Engine	V8																																										
Commodore/VT(Include VSv8)	Engine	V8 GEN III																																										
Commodore/VT(Include VSv8)	Transmission	A/T																																										
Commodore/VT(Include VSv8)	Transmission	A/T GEN III																																										
Commodore/VT(Include VSv8)	Chassis	ABS																																										
Commodore/VT(Include VSv8)	Body	SRS Airbag																																										
Commodore/VT(Include VSv8)	Body	BCM(Body control module)																																										
Commodore/VT(Include VSv8)	Body	Instrument																																										
Commodore/VT(Include VSv8)	Body	PIM(Powertrain Interface Module)																																										
Commodore/VT(Include VSv8)	Body	Climate Control																																										
Commodore/VX	Engine	V6																																										
Commodore/VX	Engine	V6 Supercharged																																										
Commodore/VX	Engine	V8 GEN III																																										
Commodore/VX	Transmission	A/T																																										
Commodore/VX	Transmission	A/T GEN III																																										
Commodore/VX	Chassis	ABS																																										
Commodore/VX	Body	SRS Airbag																																										
Commodore/VX	Body	BCM(Body control module)																																										
Commodore/VX	Body	Instrument																																										
Commodore/VX	Body	PIM(Powertrain Interface Module)																																										
Commodore/VX	Body	Climate Control																																										
Commodore/VY	Engine	V6																																										
Commodore/VY	Engine	V6 Supercharged																																										
Commodore/VY	Engine	V8 GEN III																																										

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
Commodore/VY	Transmission	A/T																																										
Commodore/VY	Transmission	A/T GEN III																																										
Commodore/VY	Chassis	ABS																																										
Commodore/VY	Body	SRS Airbag																																										
Commodore/VY	Body	BCM(Body control module)																																										
Commodore/VY	Body	Instrument																																										
Commodore/VY	Body	PIM(Powertrain Interface Module)																																										
Commodore/VY	Body	Audio System																																										
Commodore/VZ	Engine	V6																																										
Commodore/VZ	Engine	V6 Supercharged																																										
Commodore/VZ	Engine	V8 GEN III																																										
Commodore/VZ	Engine	V8 GEN IV																																										
Commodore/VZ	Transmission	A/T																																										
Commodore/VZ	Transmission	A/T GEN III																																										
Commodore/VZ	Chassis	ABS/TC/ESP8.0																																										
Commodore/VZ	Chassis	ABS/ETC																																										
Commodore/VZ	Body	SRS Airbag																																										
Commodore/VZ	Body	BCM(Body control module)																																										
Commodore/VZ	Body	PIM(Powertrain Interface Module)																																										
Commodore/VZ	Body	Instrument																																										
Commodore/VZ	Body	Audio System																																										
Commodore/VE	Engine	V6	V	V													V	V	V																									
Commodore/VE	Engine	V8 GEN IV																																										
Commodore/VE	Transmission	A/T																																										
Commodore/VE	Chassis	EBCM(Electronic brake control module)				V																																						
Commodore/VE	Chassis	TPMS(Tyre pressure monitor system)																																										
Commodore/VE	Chassis	Fuel Pump Control																																										
Commodore/VE	Body	BCM(Body control module)					V	V																																				
Commodore/VE	Body	VTM(Theft deterrent module)													V	V																												
Commodore/VE	Body	RFA(Remote function actuator)							V	V																																		
Commodore/VE	Body	SDM(SRS Airbag)									V																																	
Commodore/VE	Body	IPC(Instrument Panel Cluster)																																										
Commodore/VE	Body	HVAC(Heating Ventilating and Air Conditioning)										V	V	V																														
Commodore/VE	Body	MSM																																										
Commodore/VE	Body	Parking Assist																																										
Commodore/VE	Body	AHL																		V																								
Commodore/VE	Infotainment System	Audio System																			V																							
Commodore/VE	Infotainment System	Rear Seat Entertainment																																										

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
VF Comodore	Powertrain	3.0L LFW(Beta)																																										
VF Comodore	Powertrain	3.6L LFX																																										
VF Comodore	Powertrain	6.2L LS3(Beta)																																										
VF Comodore	Powertrain	FICM(Fuel injector control module)																																										
VF Comodore	Powertrain	TCM(Transmission control unit)																																										
VF Comodore	Chassis	CCM(Chassis control module)																																										
VF Comodore	Chassis	EBCM(Electronic brake control module)																																										
VF Comodore	Chassis	PBCM(Parking brake control module)																																										
VF Comodore	Chassis	PSCM(Power steering control module)																																										
VF Comodore	Chassis	SWASM(Steering wheel angle sensor module)																																										
VF Comodore	Chassis	SCM(Suspension control module)																																										
VF Comodore	Body	Immobilizer																																										
VF Comodore	Body	BCM(Body control module)																																										
VF Comodore	Body	SDM(Inflatable restraint sensing and diagnostic module)																																										
VF Comodore	Body	IC(Instrument cluster)																																										
VF Comodore	Body	HDM(Head-up display module)																																										
VF Comodore	Body	RCP(Radio control panel)																																										
VF Comodore	Body	HVACCP(Heating Ventilating and Air Conditioning control panel)																																										
VF Comodore	Body	Radio																																										
VF Comodore	Body	HVAC(Heating Ventilating and Air Conditioning)																																										
VF Comodore	Body	RODCM(Right side object detection control module)																																										
VF Comodore	Body	LODCM(Left side object detection control module)																																										
VF Comodore	Body	Keyless																																										
VF Comodore	Body	PACM(Parking assist control module)																																										
VF Comodore	Body	FVCM(Front view camera module)																																										
VF Comodore	Body	SCCM(Steering column lock control module)																																										
YG Cruze		Engine																																										
YG Cruze		Transmission																																										
YG Cruze		ABS																																										
YG Cruze		EPS																																										
YG Cruze		Immobilizer																																										
YG Cruze		Airbag																																										
Cruze/Gasoline	Powertrain	Engine control module(1.4L LUJ)																																										
Cruze/Gasoline	Powertrain	Engine control module(1.8L 2H0)																																										
Cruze/Gasoline	Powertrain	Fuel pump control module																																										
Cruze/Gasoline	Powertrain	Transmission control module																																										
Cruze/Gasoline	Chassis	EBCM(Electronic brake control module)																																										
Cruze/Gasoline	Chassis	Multi-Axis acceleration sensor module																																										

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
Cruze/Gasoline	Chassis	Steering wheel angle sensor module																																										
Cruze/Gasoline	Chassis	Electrinic power steering control module																																										
Cruze/Gasoline	Body	Body control module																																										
Cruze/Gasoline	Body	Immobilizer																																										
Cruze/Gasoline	Body	SDM(Inflatable restraint sensing and diagnostic module)																																										
Cruze/Gasoline	Body	Passenger presence module																																										
Cruze/Gasoline	Body	Instrument panel cluster																																										
Cruze/Gasoline	Body	Auto Heating ventilating and air conditioning																																										
Cruze/Gasoline	Body	Manual Heating ventilating and air conditioning																																										
Cruze/Gasoline	Body	Front seat heating control module																																										
Cruze/Gasoline	Body	Park assist control module																																										
Cruze/Gasoline	Body	Passive entry passive start																																										
Cruze/Gasoline	Body	Steering column lock control module																																										
Cruze/Gasoline	Infotainment	Radio																																										
Cruze/Gasoline	Infotainment	Telematics communication interface control module																																										
Cruze/Diesel	Powertrain	Engine control module(2.0L LLW)																																										
Cruze/Diesel	Powertrain	Engine control module(2.0L LNP)																																										
Cruze/Diesel	Powertrain	Fuel pump control module																																										
Cruze/Diesel	Powertrain	Transmission control module																																										
Cruze/Diesel	Chassis	EBCM(Electronic brake control module)																																										
Cruze/Diesel	Chassis	Multi-Axis acceleration sensor module																																										
Cruze/Diesel	Chassis	Steering wheel angle sensor module																																										
Cruze/Diesel	Chassis	Electrinic power steering control module																																										
Cruze/Diesel	Body	Body control module																																										
Cruze/Diesel	Body	Immobilizer																																										
Cruze/Diesel	Body	SDM(Inflatable restraint sensing and diagnostic module)																																										
Cruze/Diesel	Body	Passenger presence module																																										
Cruze/Diesel	Body	Instrument panel cluster																																										
Cruze/Diesel	Body	Auto Heating ventilating and air conditioning																																										
Cruze/Diesel	Body	Manual Heating ventilating and air conditioning																																										
Cruze/Diesel	Body	Front seat heating control module																																										
Cruze/Diesel	Body	Park assist control module																																										
Cruze/Diesel	Body	Passive entry passive start																																										
Cruze/Diesel	Body	Steering column lock control module																																										
Cruze/Diesel	Infotainment	Radio																																										
Cruze/Diesel	Infotainment	Telematics communication interface control module																																										
Barina/Spark/Barina(T300)	Powertrain	Engine control module(1.4L LUJ)																																										
Barina/Spark/Barina(T300)	Powertrain	Engine control unit(1.6L LDE)																																										

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
Barina/Spark/Barina(T300)	Powertrain	TCM(Transmission control module)																																										
Barina/Spark/Barina(T300)	Chassis	Electronic brake control module																																										
Barina/Spark/Barina(T300)	Chassis	Multi-Axis acceleration sensor module																																										
Barina/Spark/Barina(T300)	Chassis	Steering wheel angle sensor module																																										
Barina/Spark/Barina(T300)	Body	Immobilizer																																										
Barina/Spark/Barina(T300)	Body	BCM(Body control module)																																										
Barina/Spark/Barina(T300)	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																										
Barina/Spark/Barina(T300)	Body	IPC(Instrument Cluster)																																										
Barina/Spark/Barina(T300)	Information	Radio																																										
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LEB)																																										
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LMT)																																										
Barina/Spark/Barina Spark	Powertrain	Engine LPG																																										
Barina/Spark/Barina Spark	Powertrain	TCM(Transmission control module)																																										
Barina/Spark/Barina Spark	Chassis	Electronic brake control module																																										
Barina/Spark/Barina Spark	Chassis	Multi-Axis acceleration sensor module																																										
Barina/Spark/Barina Spark	Chassis	Electronic power steering control module																																										
Barina/Spark/Barina Spark	Chassis	Steering wheel angle sensor module																																										
Barina/Spark/Barina Spark	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																										
Barina/Spark/Barina Spark	Body	IPC(Instrument Cluster)																																										
Barina/Spark/Barina Spark	Body	Keyless entry control module																																										
Barina/Spark/Barina Spark	Body	Passenger presensce module																																										
Barina/Spark/Barina(OPEL)	Engine	C 14 SE																																										
Barina/Spark/Barina(OPEL)	Engine	Z 14 XE																																V	V									
Barina/Spark/Barina(OPEL)	Engine	Z 14 XEP																																										
Barina/Spark/Barina(OPEL)	Engine	Z 16 SE																															V											
Barina/Spark/Barina(OPEL)	Engine	Z 18 XE																														V	V	V	V									
Barina/Spark/Barina(OPEL)	Transmission	AF 13/14/20																																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13II/20/22/30																																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13-II/17/20/22 CAN																																										
Barina/Spark/Barina(OPEL)	Chassis	ABS 5.3/5.4 +TC																																										
Barina/Spark/Barina(OPEL)	Chassis	ABS/ESP8																																										
Barina/Spark/Barina(OPEL)	Chassis	Electronic Power Steering																																										
Barina/Spark/Barina(OPEL)	Body	Immobiliser																																										
Barina/Spark/Barina(OPEL)	Body	Body Control Module																																										
Barina/Spark/Barina(OPEL)	Body	SRS Airbag																																										
Barina/Spark/Barina(OPEL)	Body	Instrument																																										
Barina/Spark/Barina(OPEL)	Information	Read security PIN code																																										
Barina/Spark/Barina(OPEL)	Information	Trip info display																																										

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.5 Sohc																																										
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.6 Dohc																																										
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	A/T Aisin5																																										
Barina/Spark/Barina(GM/DAEWOO)	Chassis	ABS																																										
Barina/Spark/Barina(GM/DAEWOO)	Body	Immobilizer																																										
Barina/Spark/Barina(GM/DAEWOO)	Body	Keyless entry																																										
Barina/Spark/Barina(GM/DAEWOO)	Body	Air Bag																																										
Volt		ECM(Engine control module)																																										
Volt		FPCM(Fuel pump control module)																																										
Volt		HVCM(Hybrid powertrain control module)																																										
Volt		HVCM2(Hybrid powertrain control module 2)																																										
Volt		TCM(Transmission control module)																																										
Volt		DMCM1(Driver motor control module 1)																																										
Volt		DMCM2(Driver motor control module 2)																																										
Volt		BCCM(Battery charger control module)																																										
Volt		BECM(Battery energy control module)																																										
Volt		ATFP(Auxiliary transmission fluid pump)																																										
Volt		EBCM(Electronic brake control module)																																										
Volt		PBCM(Parking brake control module)																																										
Volt		MAASM(Multi axis acceleration sensor module)																																										
Volt		PSCM(Power steering control module)																																										
Volt		SWASM(Steering wheel angle sensor module)																																										
Volt		Immobilizer																																										
Volt		BCM(Body control module)																																										
Volt		SDM(Inflatable restraint sensing and diagnostic module)																																										
Volt		IC(Instrument cluster)																																										
Volt		Radio																																										
Volt		TCIC(Telematics communication interface control module)																																										
Volt		HVAC(Heating Ventilating and Air Conditioning)																																										
Volt		CHCM(Coolant heater control module)																																										
Volt		SHCM(Seat heating control module)																																										
Volt		Keyless																																										
Volt		PACM(Parking assist control module)																																										
Volt		FVC(Front view camera)																																										
Volt		SCCM(Steering column lock control module)																																										
Captiva/Captiva	Powertrain	Engine Diesel																																										
Captiva/Captiva	Powertrain	Engine 2.4 Dohc																																										
Captiva/Captiva	Powertrain	Engine 3.2 Dohc																																										

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
Captiva/Captiva	Powertrain	Auto Transmission																																										
Captiva/Captiva	Chassis	EBCM(Electronic brake control module)																																										
Captiva/Captiva	Chassis	TCCM(Transfer case control module)																																										
Captiva/Captiva	Body	SDM(SRS Airbag)																																										
Captiva/Captiva	Body	IPC(Instrument panel cluster)																																										
Captiva/Captiva	Body	BCM(Body control module)																																										
Captiva/Captiva	Body	VTD(Theft deterrent module)																																										
Captiva/Captiva	Body	RFA(Remote function actuator)																																										
Captiva/Captiva 5/7	Powertrain	Engine control module(2.2L LNQ)																																										
Captiva/Captiva 5/7	Powertrain	Engine control module(2.4L LE5)																																										
Captiva/Captiva 5/7	Powertrain	Engine control module(3.0L LF1)																																										
Captiva/Captiva 5/7	Powertrain	Fuel pump control module																																										
Captiva/Captiva 5/7	Powertrain	Transmission control module																																										
Captiva/Captiva 5/7	Chassis	Electronic brake control module																																										
Captiva/Captiva 5/7	Chassis	Parking brake control module																																										
Captiva/Captiva 5/7	Chassis	Rear differential clutch control module																																										
Captiva/Captiva 5/7	Body	Body control module																																										
Captiva/Captiva 5/7	Body	Inflatable restraint sensing and diagnostic module																																										
Captiva/Captiva 5/7	Body	Instrument panel cluster																																										
Captiva/Captiva 5/7	Body	HVAC control module																																										
Captiva/Captiva 5/7	Body	Remote control door lock receiver																																										
Captiva/Captiva 5/7	Body	Theft deterrent module																																										
Captiva/Captiva 5/7	Body	Parking assist control module																																										
Captiva/Captiva 5/7	Infotainment	Radio																																										
VIVA		1.4/1.5 Dohc																																										
VIVA		1.6 Dohc																																										
VIVA		1.8 Dohc																																										
VIVA		A/T																																										
VIVA		ABS																																										
VIVA		SSPS																																										
VIVA		Immobilizer																																										
VIVA		Keyless entry																																										
VIVA		Air Bag																																										
Malibu		ECM 2.4L(Engine control module 2.4L LE9)																																										
Malibu		ECM 2.0L(Engine control module 2.0L LBS)																																										
Malibu		TCM(Transmission control module)																																										
Malibu		EBCM(Electronic brake control module)																																										
Malibu		MAASM(Multi axis acceleration sensor module)																																										

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
Malibu		PSCM(Power steering control module)																																										
Malibu		SWASM(Steering wheel angle sensor module)																																										
Malibu		Immobilizer																																										
Malibu		BCM(Body control module)																																										
Malibu		SDM(Inflatable restraint sensing and diagnostic module)																																										
Malibu		IC(Instrument cluster)																																										
Malibu		Radio																																										
Malibu		HVAC(Heating Ventilating and Air Conditioning)																																										
Malibu		Keyless																																										
Malibu		PACM(Parking assist control module)																																										
Malibu		SCCM(Steering column lock control module)																																										
Epica		2.0 Dohc(Beta)																																										
Epica		Engine Diesel																																										
Epica		A/T Aisin5(Beta)																																										
Epica		A/T GF 6																																										
Epica		ABS																																										
Epica		SSPS																																										
Epica		SDM(SRS AIRBAG)																																										
Epica		Keyless entry																																										
Epica		ISU/BCM																																										
Astra/Astra-F	Engine	C16SE																																										
Astra/Astra-F	Engine	C18SEL																							V	V	V	V																
Astra/Astra-F	Transmission	AF 13/14/20																																										
Astra/Astra-F	Transmission	AF 13II/20/22/30																																										
Astra/Astra-F	Body	Immobilizer																																										
Astra/Astra-F	Body	Airbag-S																																										
Astra/Astra-G	Engine	Z 18 XE																														V	V	V	V									
Astra/Astra-G	Engine	X 18 XE1																							V	V	V																	
Astra/Astra-G	Engine	Z 22 SE																															V											
Astra/Astra-G	Transmission	AF 13-II/17/20/22																																										
Astra/Astra-G	Transmission	AF 13-II/17/20/22 CAN																																										
Astra/Astra-G	Chassis	ABS 5.3/5.4 +TC																																										
Astra/Astra-G	Chassis	ESP																																										
Astra/Astra-G	Chassis	Electronic Power Steering																																										
Astra/Astra-G	Body	Immobiliser																																										
Astra/Astra-G	Body	SRS Airbag																																										
Astra/Astra-G	Body	Instrument																																										
Astra/Astra-G	Body	Engine Cooling Module																																										

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
Astra/Astra-G	Body	Add On Heater																																										
Astra/Astra-G	Body	Electronic Climate Control																																										
Astra/Astra-G	Body	Central Door Lock																																										
Astra/Astra-G	Body	Softtop Controller																																										
Astra/Astra-G	Information	Read security PIN code																																										
Astra/Astra-G	Infortainment System	Trip Info Display																																										
Astra/Astra-G	Infortainment System	Multi Info Display																																										
Astra/Astra-H	Engine	Z 18 XE																																		V	V	V						
Astra/Astra-H	Engine	Z 18 XER																																		V	V	V						
Astra/Astra-H	Engine	Z 19 DT(Beta)																																			V		V	V	V	V	V
Astra/Astra-H	Engine	Z 20 LEH																																					V					
Astra/Astra-H	Engine	Z 20 LER																																		V	V							
Astra/Astra-H	Engine	Z 22 YH																																		V	V							
Astra/Astra-H	Transmission	AF 40-6(Beta)																																										
Astra/Astra-H	Transmission	AF 22-4																																										
Astra/Astra-H	Transmission	AF 17-4																																										
Astra/Astra-H	Chassis	ABS/TC/ESP																																										
Astra/Astra-H	Chassis	EHPS(Electrohydraulic power steering)																																										
Astra/Astra-H	Body	SDM(Airbag)																																										
Astra/Astra-H	Body	CIM(Steering column module)																																										
Astra/Astra-H	Body	IPC(Instrument control unit)																																										
Astra/Astra-H	Body	UEC(Underhood electrical centre)																																										
Astra/Astra-H	Body	REC(Rear electrical centre)																																										
Astra/Astra-H	Body	PAS(Park pilot)																																										
Astra/Astra-H	Body	SAC(Air conditioning)																																										
Astra/Astra-H	Body	Electrohydraulic hard top																																										
Combo/Corsa-B	Engine	C 14 SE																																										
Combo/Corsa-B	Engine	Z 14 XE																															V											
Combo/Corsa-B	Engine	Z 14 XEP																																										
Combo/Corsa-B	Engine	Z 16 SE																															V											
Combo/Corsa-B	Engine	Z 18 XE																														V	V	V	V									
Combo/Corsa-B	Transmission	AF 13/14/20																																										
Combo/Corsa-B	Transmission	AF 13II/20/22/30																																										
Combo/Corsa-B	Transmission	AF 13-II/17/20/22 CAN																																										
Combo/Corsa-B	Chassis	ABS 5.3/5.4 +TC																																										
Combo/Corsa-B	Chassis	ABS/ESP8																																										
Combo/Corsa-B	Chassis	Electronic Power Steering																																										
Combo/Corsa-B	Body	Immobiliser																																										

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
Combo/Corsa-B	Body	Body Control Module																																										
Combo/Corsa-B	Body	SRS Airbag																																										
Combo/Corsa-B	Body	Instrument																																										
Combo/Corsa-B	Information	Trip info display																																										
Combo/Corsa-C	Engine	Z 14 XE																															V											
Combo/Corsa-C	Engine	Z 14 XEP																																										
Combo/Corsa-C	Engine	Z 16 SE																															V											
Combo/Corsa-C	Engine	Z 18 XE																														V	V	V	V									
Combo/Corsa-C	Transmission	AF 13-II/17/20/22 CAN																																										
Combo/Corsa-C	Chassis	ABS 5.3/5.4 +TC																																										
Combo/Corsa-C	Chassis	Electronic Power Steering																																										
Combo/Corsa-C	Body	Immobiliser																																										
Combo/Corsa-C	Body	Body Control Module																																										
Combo/Corsa-C	Body	SRS Airbag																																										
Combo/Corsa-C	Body	Instrument																																										
Combo/Corsa-C	Information	Read security PIN code																																										
Trax		Engine Control Module 1.4L - 2WD																																										
Trax		Engine Control Module 1.4L - AWD																																										
Trax		Engine Control Module 1.8L - 2WD																																										
Trax		Engine Control Module 1.8L - AWD																																										
Trax		Engine Control Module 1.7L																																										
Trax		Transmission																																										
Trax		Rear Differential Clutch Control Module - Beta																																										
Trax		EBCM(Electronic brake control module)																																										
Trax		PSCM(Power steering control module)																																										
Trax		SWASM(Steering wheel angle sensor module)																																										
Trax		Immobilizer																																										
Trax		BCM(Body control module)																																										
Trax		SDM(Inflatable restraint sensing and diagnostic module)																																										
Trax		IC(Instrument cluster)																																										
Trax		Radio																																										
Trax		HVAC(Heating Ventilating and Air Conditioning)																																										
Trax		SHCM(Seat heating control module)																																										
Trax		PACM(Parking assist control module)																																										
Jackaroo/Monterey	Engine	6VD1																																										
Jackaroo/Monterey	Engine	3.0 L4 4JX1																																										
Jackaroo/Monterey	Engine	3.2 V6 6VD1 Hitachi																																										
Jackaroo/Monterey	Engine	3.5 V6 6VE1 Hitachi																																										

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
Jackaroo/Monterey	Transmission	4L30E																																										
Jackaroo/Monterey	Transmission	AW30-40LE																																										
Jackaroo/Monterey	Body	Immobilizer																																										
Jackaroo/Monterey	Body	Airbag																																										
Jackaroo/Monterey	Body	Aniti theft warning																																										
Rodeo/Colorado/Rodeo	Engine	6VD1																																										
Rodeo/Colorado/Rodeo	Engine	2.2 L4 SOHC																																										
Rodeo/Colorado/Rodeo	Engine	2.X L4 HV240																																										
Rodeo/Colorado/Rodeo	Engine	3.2 V6 6VD1 Hitachi																																										
Rodeo/Colorado/Rodeo	Transmission	4L30E																																										
Rodeo/Colorado/Rodeo	Transmission	AW30-40LE																																										
Rodeo/Colorado/Rodeo	Body	Immobilizer																																										
Rodeo/Colorado/Rodeo	Body	Aniti theft warning																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.2 L4 SOHC																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.4 LP1 EURO3																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.X L4 HV240																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.0 iTD(4JH1-TC)																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.5 V6 6VE1 Hitachi																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	V6 Engine																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AT JR405E																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AW30-40LE																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	Auto transmission																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Chassis	ABS																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Immobilizer																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	PIM(Powertrain interface module)																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	SRS airbag																																										
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Aniti theft warning																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	2.4 LP1 EURO3																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Delphi)																																						V				
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Transtron)																																						V				
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	V6 Engine																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Chassis	ABS																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	AW30-40LE																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	Auto transmission																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Immobilizer(V6 Engine)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	SRS(Airbag)																																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Aniti theft warning																																										
New Colorado/Colorado7	Engine	2.8L Diesel(LWH)																																										

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU4																																									
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU5																																									
New Colorado/Colorado7	Chassis	Electronic brake control module																																									
New Colorado/Colorado7	Chassis	Transfer case control module																																									
New Colorado/Colorado7	Chassis	Steering wheel angle sensor module																																									
New Colorado/Colorado7	Chassis	Multi-Axis acceleration sensor module																																									
New Colorado/Colorado7	Transmission	Auto transmission(6SP)																																									
New Colorado/Colorado7	Body	Immobilizer(New Colorado)																																									
New Colorado/Colorado7	Body	Body Control Module																																									
New Colorado/Colorado7	Body	Instrument cluster																																									
New Colorado/Colorado7	Body	SRS(Airbag)																																									
Tigra/Tigra-B	Engine	C 14 SE																																									
Tigra/Tigra-B	Engine	Z 14 XE																															V										
Tigra/Tigra-B	Engine	Z 14 XEP																																									
Tigra/Tigra-B	Engine	Z 16 SE																															V										
Tigra/Tigra-B	Engine	Z 18 XE																														V	V	V	V								
Tigra/Tigra-B	Transmission	AF 13/14/20																																									
Tigra/Tigra-B	Transmission	AF 13II/20/22/30																																									
Tigra/Tigra-B	Transmission	AF 13-II/17/20/22 CAN																																									
Tigra/Tigra-B	Chassis	ABS 5.3/5.4 +TC																																									
Tigra/Tigra-B	Chassis	ABS/ESP8																																									
Tigra/Tigra-B	Chassis	Electronic Power Steering																																									
Tigra/Tigra-B	Body	Immobiliser																																									
Tigra/Tigra-B	Body	Body Control Module																																									
Tigra/Tigra-B	Body	SRS Airbag																																									
Tigra/Tigra-B	Body	Instrument																																									
Tigra/Tigra-B	Information	Read security PIN code																																									
Tigra/Tigra-B	Information	Trip info display																																									
Vectra/Vectra-B	Engine	C 20 SEL																							V	V	V																
Vectra/Vectra-B	Engine	C 22 SEL																							V		V	V															
Vectra/Vectra-B	Engine	Z 22 SE																																									
Vectra/Vectra-B	Engine	X 25 XE																							V				V		V												
Vectra/Vectra-B	Engine	Y 26 SE																																									
Vectra/Vectra-B	Transmission	AF 13/14/20																																									
Vectra/Vectra-B	Transmission	AF 13II/20/22/30																																									
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22																																									
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22 CAN																																									
Vectra/Vectra-B	Chassis	ABS 5.3/5.4 +TC																																									

Model	Group	System	RESET ENGINE OIL LIFE	THROTTLE BODY RELEARN	Tap cells reset	Calibration Steering Angle Sensor	Actuator Test	VE_Brake Pedal Position Sensor Lea	VE_RFM_Additional_Remote	VE_RFM_Erase_Program_Remote	VE_SDM Primary key to BCM	Blower operating time rest	Calibration HVAC doors	Module installation	Reprogram All Transponder Key	Program Additional Keys	Idle learn reset	Oil life reset	Crankshaft position system variant reset	Auto Headlamp levelling	Facia Link to IRC	TPMS Learning/Matching procedure	Calibration steering angle sensor	Brake pressure sensor calibration	Adjust idle speed	Adjust idle drive	Injector Cutoff	Idle air control	Adjust idle speed offset	Reset O2-Loop block learn mapontrol	Reset IAC block learn map	Reset Learned Valves	Fuel tank ventilation control	Programing variant configuration	Program CAN configuration	Fuel pump relay test	Program tyre circumference	Injection cutoff test	Fule pump relay test	Injector programming	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor
Vectra/Vectra-B	Body	Immobiliser																																										
Vectra/Vectra-B	Body	SRS Airbag SAB6																																										
Vectra/Vectra-B	Body	Central Door Lock																																										
Vectra/Vectra-B	Body	Instrument																																										
Vectra/Vectra-B	Information	Read security PIN code																																										
Vectra/Vectra-B	Infotainment System	Trip info display																																										
Vectra/Vectra-C	Engine	Z 32 SE																																		V	V	V						
Vectra/Vectra-C	Transmission	AF 23-5/33-5/40-6																																										
Vectra/Vectra-C	Chassis	ABS/TC/ESP																																										
Vectra/Vectra-C	Chassis	EHPS(Electrohydraulic power steering)																																										
Vectra/Vectra-C	Body	SDM(Airbag)																																										
Vectra/Vectra-C	Body	CIM(Steering column module)																																										
Vectra/Vectra-C	Body	BCM(Body control module)																																										
Vectra/Vectra-C	Body	IPC(Instrument control unit)																																										
Vectra/Vectra-C	Body	REC(Rear electrical control)																																										
Vectra/Vectra-C	Body	UEC(Underhood electrical control)																																										
Vectra/Vectra-C	Body	DDM(Driver door module)																																										
Vectra/Vectra-C	Body	PDM(Passenger door module)																																										
Vectra/Vectra-C	Body	SLM(Shift lever module)																																										
Vectra/Vectra-C	Body	Electronic seat																																										
Vectra/Vectra-C	Information	Read security PIN code																																										
Zafira/2001-2005	Engine	Z 22 SE																															V											
Zafira/2001-2005	Transmission	AF 13-II/17/20/22 CAN																																										
Zafira/2001-2005	Chassis	ABS 5.3/5.4 +TC																																										
Zafira/2001-2005	Chassis	Electronic Power Steering																																										
Zafira/2001-2005	Body	Immobiliser																																										
Zafira/2001-2005	Body	SRS Airbag																																										
Zafira/2001-2005	Body	Instrument																																										
Zafira/2001-2005	Body	Engine Cooling Module																																										
Zafira/2001-2005	Body	Central Door Lock																																										
Zafira/2001-2005	Information	Read security PIN code																																										
Zafira/2001-2005	Infortainment System	Trip Info Display																																										

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
Commodore/VR	Engine	V6/V8																																			
Commodore/VR	Transmission	A/T																																			
Commodore/VR	Chassis	ABS																																			
Commodore/VR	Body	SRS Airbag																																			
Commodore/VR	Body	BCM(Body control module)																																			
Commodore/VR	Body	TDM																																			
Commodore/VS	Engine	V6																																			
Commodore/VS	Engine	V8																																			
Commodore/VS	Transmission	V6 A/T																																			
Commodore/VS	Transmission	V8 A/T																																			
Commodore/VS	Chassis	ABS																																			
Commodore/VS	Body	SRS Airbag																																			
Commodore/VS	Body	BCM(Body control module)																																			
Commodore/VT(Include VSv8)	Engine	V6																																			
Commodore/VT(Include VSv8)	Engine	V8																																			
Commodore/VT(Include VSv8)	Engine	V8 GEN III																																			
Commodore/VT(Include VSv8)	Transmission	A/T																																			
Commodore/VT(Include VSv8)	Transmission	A/T GEN III																																			
Commodore/VT(Include VSv8)	Chassis	ABS																																			
Commodore/VT(Include VSv8)	Body	SRS Airbag																																			
Commodore/VT(Include VSv8)	Body	BCM(Body control module)																																			
Commodore/VT(Include VSv8)	Body	Instrument																																			
Commodore/VT(Include VSv8)	Body	PIM(Powertrain Interface Module)																																			
Commodore/VT(Include VSv8)	Body	Climate Control																																			
Commodore/VX	Engine	V6																																			
Commodore/VX	Engine	V6 Supercharged																																			
Commodore/VX	Engine	V8 GEN III																																			
Commodore/VX	Transmission	A/T																																			
Commodore/VX	Transmission	A/T GEN III																																			
Commodore/VX	Chassis	ABS																																			
Commodore/VX	Body	SRS Airbag																																			
Commodore/VX	Body	BCM(Body control module)																																			
Commodore/VX	Body	Instrument																																			
Commodore/VX	Body	PIM(Powertrain Interface Module)																																			
Commodore/VX	Body	Climate Control																																			
Commodore/VY	Engine	V6																																			
Commodore/VY	Engine	V6 Supercharged																																			
Commodore/VY	Engine	V8 GEN III																																			

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
Commodore/VY	Transmission	A/T																																			
Commodore/VY	Transmission	A/T GEN III																																			
Commodore/VY	Chassis	ABS																																			
Commodore/VY	Body	SRS Airbag																																			
Commodore/VY	Body	BCM(Body control module)																																			
Commodore/VY	Body	Instrument																																			
Commodore/VY	Body	PIM(Powertrain Interface Module)																																			
Commodore/VY	Body	Audio System																																			
Commodore/VZ	Engine	V6																																			
Commodore/VZ	Engine	V6 Supercharged																																			
Commodore/VZ	Engine	V8 GEN III																																			
Commodore/VZ	Engine	V8 GEN IV																																			
Commodore/VZ	Transmission	A/T																																			
Commodore/VZ	Transmission	A/T GEN III																																			
Commodore/VZ	Chassis	ABS/TC/ESP8.0																																			
Commodore/VZ	Chassis	ABS/ETC																																			
Commodore/VZ	Body	SRS Airbag																																			
Commodore/VZ	Body	BCM(Body control module)																																			
Commodore/VZ	Body	PIM(Powertrain Interface Module)																																			
Commodore/VZ	Body	Instrument																																			
Commodore/VZ	Body	Audio System																																			
Commodore/VE	Engine	V6																																			
Commodore/VE	Engine	V8 GEN IV																																			
Commodore/VE	Transmission	A/T																																			
Commodore/VE	Chassis	EBCM(Electronic brake control module)																																			
Commodore/VE	Chassis	TPMS(Tyre pressure monitor system)																																			
Commodore/VE	Chassis	Fuel Pump Control																																			
Commodore/VE	Body	BCM(Body control module)																																			
Commodore/VE	Body	VTM(Theft deterrent module)																																			
Commodore/VE	Body	RFA(Remote function actuator)																																			
Commodore/VE	Body	SDM(SRS Airbag)																																			
Commodore/VE	Body	IPC(Instrument Panel Cluster)																																			
Commodore/VE	Body	HVAC(Heating Ventilating and Air Conditioning)																																			
Commodore/VE	Body	MSM																																			
Commodore/VE	Body	Parking Assist																																			
Commodore/VE	Body	AHL																																			
Commodore/VE	Infotainment System	Audio System																																			
Commodore/VE	Infotainment System	Rear Seat Entertainment																																			

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
VF Comodore	Powertrain	3.0L LFW(Beta)																																			
VF Comodore	Powertrain	3.6L LFX																																			
VF Comodore	Powertrain	6.2L LS3(Beta)																																			
VF Comodore	Powertrain	FICM(Fuel injector control module)																																			
VF Comodore	Powertrain	TCM(Transmission control unit)																																			
VF Comodore	Chassis	CCM(Chassis control module)																																			
VF Comodore	Chassis	EBCM(Electronic brake control module)																																			
VF Comodore	Chassis	PBCM(Parking brake control module)																																			
VF Comodore	Chassis	PSCM(Power steering control module)																																			
VF Comodore	Chassis	SWASM(Steering wheel angle sensor module)																																			
VF Comodore	Chassis	SCM(Suspension control module)																																			
VF Comodore	Body	Immobilizer																																			
VF Comodore	Body	BCM(Body control module)																																			
VF Comodore	Body	SDM(Inflatable restraint sensing and diagnostic module)																																			
VF Comodore	Body	IC(Instrument cluster)																																			
VF Comodore	Body	HDM(Head-up display module)																																			
VF Comodore	Body	RCP(Radio control panel)																																			
VF Comodore	Body	HVACCP(Heating Ventilating and Air Conditioning control panel)																																			
VF Comodore	Body	Radio																																			
VF Comodore	Body	HVAC(Heating Ventilating and Air Conditioning)																																			
VF Comodore	Body	RODCM(Right side object detection control module)																																			
VF Comodore	Body	LODCM(Left side object detection control module)																																			
VF Comodore	Body	Keyless																																			
VF Comodore	Body	PACM(Parking assist control module)																																			
VF Comodore	Body	FVCM(Front view camera module)																																			
VF Comodore	Body	SCCM(Steering column lock control module)																																			
YG Cruze		Engine																																			
YG Cruze		Transmission																																			
YG Cruze		ABS																																			
YG Cruze		EPS																																			
YG Cruze		Immobilizer													V	V																					
YG Cruze		Airbag																																			
Cruze/Gasoline	Powertrain	Engine control module(1.4L LUJ)																																			
Cruze/Gasoline	Powertrain	Engine control module(1.8L 2H0)																																			
Cruze/Gasoline	Powertrain	Fuel pump control module																																			
Cruze/Gasoline	Powertrain	Transmission control module																																			
Cruze/Gasoline	Chassis	EBCM(Electronic brake control module)																																			
Cruze/Gasoline	Chassis	Multi-Axis acceleration sensor module																																			

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
Cruze/Gasoline	Chassis	Steering wheel angle sensor module																																			
Cruze/Gasoline	Chassis	Electrinic power steering control module																																			
Cruze/Gasoline	Body	Body control module																																			
Cruze/Gasoline	Body	Immobilizer																																			
Cruze/Gasoline	Body	SDM(Inflatable restraint sensing and diagnostic module)																																			
Cruze/Gasoline	Body	Passenger presence module																																			
Cruze/Gasoline	Body	Instrument panel cluster																																			
Cruze/Gasoline	Body	Auto Heating ventilating and air conditioning																																			
Cruze/Gasoline	Body	Manual Heating ventilating and air conditioning																																			
Cruze/Gasoline	Body	Front seat heating control module																																			
Cruze/Gasoline	Body	Park assist control module																																			
Cruze/Gasoline	Body	Passive entry passive start																																			
Cruze/Gasoline	Body	Steering column lock control module																																			
Cruze/Gasoline	Infotainment	Radio																																			
Cruze/Gasoline	Infotainment	Telematics communication interface control module																																			
Cruze/Diesel	Powertrain	Engine control module(2.0L LLW)																																			
Cruze/Diesel	Powertrain	Engine control module(2.0L LNP)																																			
Cruze/Diesel	Powertrain	Fuel pump control module																																			
Cruze/Diesel	Powertrain	Transmission control module																																			
Cruze/Diesel	Chassis	EBCM(Electronic brake control module)																																			
Cruze/Diesel	Chassis	Multi-Axis acceleration sensor module																																			
Cruze/Diesel	Chassis	Steering wheel angle sensor module																																			
Cruze/Diesel	Chassis	Electrinic power steering control module																																			
Cruze/Diesel	Body	Body control module																																			
Cruze/Diesel	Body	Immobilizer																																			
Cruze/Diesel	Body	SDM(Inflatable restraint sensing and diagnostic module)																																			
Cruze/Diesel	Body	Passenger presence module																																			
Cruze/Diesel	Body	Instrument panel cluster																																			
Cruze/Diesel	Body	Auto Heating ventilating and air conditioning																																			
Cruze/Diesel	Body	Manual Heating ventilating and air conditioning																																			
Cruze/Diesel	Body	Front seat heating control module																																			
Cruze/Diesel	Body	Park assist control module																																			
Cruze/Diesel	Body	Passive entry passive start																																			
Cruze/Diesel	Body	Steering column lock control module																																			
Cruze/Diesel	Infotainment	Radio																																			
Cruze/Diesel	Infotainment	Telematics communication interface control module																																			
Barina/Spark/Barina(T300)	Powertrain	Engine control module(1.4L LUJ)																																			
Barina/Spark/Barina(T300)	Powertrain	Engine control unit(1.6L LDE)																																			

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
Barina/Spark/Barina(T300)	Powertrain	TCM(Transmission control module)																																			
Barina/Spark/Barina(T300)	Chassis	Electronic brake control module																																			
Barina/Spark/Barina(T300)	Chassis	Multi-Axis acceleration sensor module																																			
Barina/Spark/Barina(T300)	Chassis	Steering wheel angle sensor module																																			
Barina/Spark/Barina(T300)	Body	Immobilizer																																			
Barina/Spark/Barina(T300)	Body	BCM(Body control module)																																			
Barina/Spark/Barina(T300)	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																			
Barina/Spark/Barina(T300)	Body	IPC(Instrument Cluster)																																			
Barina/Spark/Barina(T300)	Information	Radio																																			
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LEB)																																			
Barina/Spark/Barina Spark	Powertrain	Engine control unit(1.0L LMT)																																			
Barina/Spark/Barina Spark	Powertrain	Engine LPG																																			
Barina/Spark/Barina Spark	Powertrain	TCM(Transmission control module)																																			
Barina/Spark/Barina Spark	Chassis	Electronic brake control module																																			
Barina/Spark/Barina Spark	Chassis	Multi-Axis acceleration sensor module																																			
Barina/Spark/Barina Spark	Chassis	Electronic power steering control module																																			
Barina/Spark/Barina Spark	Chassis	Steering wheel angle sensor module																																			
Barina/Spark/Barina Spark	Body	SDM(Inflatable restraintment sensing and diagnostic module)																																			
Barina/Spark/Barina Spark	Body	IPC(Instrument Cluster)																																			
Barina/Spark/Barina Spark	Body	Keyless entry control module																																			
Barina/Spark/Barina Spark	Body	Passenger presensce module																																			
Barina/Spark/Barina(OPEL)	Engine	C 14 SE																																			
Barina/Spark/Barina(OPEL)	Engine	Z 14 XE																																			
Barina/Spark/Barina(OPEL)	Engine	Z 14 XEP																																			
Barina/Spark/Barina(OPEL)	Engine	Z 16 SE																																			
Barina/Spark/Barina(OPEL)	Engine	Z 18 XE																																			
Barina/Spark/Barina(OPEL)	Transmission	AF 13/14/20																																			
Barina/Spark/Barina(OPEL)	Transmission	AF 13II/20/22/30									V																										
Barina/Spark/Barina(OPEL)	Transmission	AF 13-II/17/20/22 CAN																																			
Barina/Spark/Barina(OPEL)	Chassis	ABS 5.3/5.4 +TC																																			
Barina/Spark/Barina(OPEL)	Chassis	ABS/ESP8																																			
Barina/Spark/Barina(OPEL)	Chassis	Electronic Power Steering																																			
Barina/Spark/Barina(OPEL)	Body	Immobiliser																V	V	V	V	V	V														
Barina/Spark/Barina(OPEL)	Body	Body Control Module																																V			
Barina/Spark/Barina(OPEL)	Body	SRS Airbag																										V	V	V							
Barina/Spark/Barina(OPEL)	Body	Instrument																														V					
Barina/Spark/Barina(OPEL)	Information	Read security PIN code																																			
Barina/Spark/Barina(OPEL)	Information	Trip info display																																			

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.5 Sohc																																			
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	1.6 Dohc																																			
Barina/Spark/Barina(GM/DAEWOO)	Powertrain	A/T Aisin5																																			
Barina/Spark/Barina(GM/DAEWOO)	Chassis	ABS																																			
Barina/Spark/Barina(GM/DAEWOO)	Body	Immobilizer																																			
Barina/Spark/Barina(GM/DAEWOO)	Body	Keyless entry																																			
Barina/Spark/Barina(GM/DAEWOO)	Body	Air Bag																																			
Volt		ECM(Engine control module)																																			
Volt		FPCM(Fuel pump control module)																																			
Volt		HVCM(Hybrid powertrain control module)																																			
Volt		HVCM2(Hybrid powertrain control module 2)																																			
Volt		TCM(Transmission control module)																																			
Volt		DMCM1(Driver motor control module 1)																																			
Volt		DMCM2(Driver motor control module 2)																																			
Volt		BCCM(Battery charger control module)																																			
Volt		BECM(Battery energy control module)																																			
Volt		ATFP(Auxiliary transmission fluid pump)																																			
Volt		EBCM(Electronic brake control module)																																			
Volt		PBCM(Parking brake control module)																																			
Volt		MAASM(Multi axis acceleration sensor module)																																			
Volt		PSCM(Power steering control module)																																			
Volt		SWASM(Steering wheel angle sensor module)																																			
Volt		Immobilizer																																			
Volt		BCM(Body control module)																																			
Volt		SDM(Inflatable restraint sensing and diagnostic module)																																			
Volt		IC(Instrument cluster)																																			
Volt		Radio																																			
Volt		TCIC(Telematics communication interface control module)																																			
Volt		HVAC(Heating Ventilating and Air Conditioning)																																			
Volt		CHCM(Coolant heater control module)																																			
Volt		SHCM(Seat heating control module)																																			
Volt		Keyless																																			
Volt		PACM(Parking assist control module)																																			
Volt		FVC(Front view camera)																																			
Volt		SCCM(Steering column lock control module)																																			
Captiva/Captiva	Powertrain	Engine Diesel																																			
Captiva/Captiva	Powertrain	Engine 2.4 Dohc																																			
Captiva/Captiva	Powertrain	Engine 3.2 Dohc																																			

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
Captiva/Captiva	Powertrain	Auto Transmission																																			
Captiva/Captiva	Chassis	EBCM(Electronic brake control module)																																			
Captiva/Captiva	Chassis	TCCM(Transfer case control module)																																			
Captiva/Captiva	Body	SDM(SRS Airbag)																																			
Captiva/Captiva	Body	IPC(Instrument panel cluster)																																			
Captiva/Captiva	Body	BCM(Body control module)																																			
Captiva/Captiva	Body	VTD(Theft deterrent module)													V	V																					
Captiva/Captiva	Body	RFA(Remote function actuator)																																			
Captiva/Captiva 5/7	Powertrain	Engine control module(2.2L LNQ)																																			
Captiva/Captiva 5/7	Powertrain	Engine control module(2.4L LE5)																																			
Captiva/Captiva 5/7	Powertrain	Engine control module(3.0L LF1)																																			
Captiva/Captiva 5/7	Powertrain	Fuel pump control module																																			
Captiva/Captiva 5/7	Powertrain	Transmission control module																																			
Captiva/Captiva 5/7	Chassis	Electronic brake control module																																			
Captiva/Captiva 5/7	Chassis	Parking brake control module																																			
Captiva/Captiva 5/7	Chassis	Rear differential clutch control module																																			
Captiva/Captiva 5/7	Body	Body control module																																			
Captiva/Captiva 5/7	Body	Inflatable restraint sensing and diagnostic module																																			
Captiva/Captiva 5/7	Body	Instrument panel cluster																																			
Captiva/Captiva 5/7	Body	HVAC control module																																			
Captiva/Captiva 5/7	Body	Remote control door lock receiver																																			
Captiva/Captiva 5/7	Body	Theft deterrent module													V	V																					
Captiva/Captiva 5/7	Body	Parking assist control module																																			
Captiva/Captiva 5/7	Infotainment	Radio																																			
VIVA		1.4/1.5 Dohc																																			
VIVA		1.6 Dohc																																			
VIVA		1.8 Dohc																																			
VIVA		A/T																																			
VIVA		ABS																																			
VIVA		SSPS																																			
VIVA		Immobilizer																																			
VIVA		Keyless entry																																			
VIVA		Air Bag																																			
Malibu		ECM 2.4L(Engine control module 2.4L LE9)																																			
Malibu		ECM 2.0L(Engine control module 2.0L LBS)																																			
Malibu		TCM(Transmission control module)																																			
Malibu		EBCM(Electronic brake control module)																																			
Malibu		MAASM(Multi axis acceleration sensor module)																																			

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
Malibu		PSCM(Power steering control module)																																			
Malibu		SWASM(Steering wheel angle sensor module)																																			
Malibu		Immobilizer																																			
Malibu		BCM(Body control module)																																			
Malibu		SDM(Inflatable restraint sensing and diagnostic module)																																			
Malibu		IC(Instrument cluster)																																			
Malibu		Radio																																			
Malibu		HVAC(Heating Ventilating and Air Conditioning)																																			
Malibu		Keyless																																			
Malibu		PACM(Parking assist control module)																																			
Malibu		SCCM(Steering column lock control module)																																			
Epica		2.0 Dohc(Beta)																																			
Epica		Engine Diesel																																			
Epica		A/T Aisin5(Beta)																																			
Epica		A/T GF 6																																			
Epica		ABS																																			
Epica		SSPS																																			
Epica		SDM(SRS AIRBAG)																																			
Epica		Keyless entry																																			
Epica		ISU/BCM																																			
Astra/Astra-F	Engine	C16SE																																			
Astra/Astra-F	Engine	C18SEL																																			
Astra/Astra-F	Transmission	AF 13/14/20																																			
Astra/Astra-F	Transmission	AF 13II/20/22/30									V																										
Astra/Astra-F	Body	Immobilizer																																			
Astra/Astra-F	Body	Airbag-S																																			
Astra/Astra-G	Engine	Z 18 XE																																			
Astra/Astra-G	Engine	X 18 XE1																																			
Astra/Astra-G	Engine	Z 22 SE																																			
Astra/Astra-G	Transmission	AF 13-II/17/20/22									V																										
Astra/Astra-G	Transmission	AF 13-II/17/20/22 CAN																																			
Astra/Astra-G	Chassis	ABS 5.3/5.4 +TC																																			
Astra/Astra-G	Chassis	ESP																																			
Astra/Astra-G	Chassis	Electronic Power Steering																																			
Astra/Astra-G	Body	Immobiliser																V	V	V	V	V	V														
Astra/Astra-G	Body	SRS Airbag																																			
Astra/Astra-G	Body	Instrument																														V					
Astra/Astra-G	Body	Engine Cooling Module																																			

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
Astra/Astra-G	Body	Add On Heater																																			
Astra/Astra-G	Body	Electronic Climate Control																																			
Astra/Astra-G	Body	Central Door Lock																																			
Astra/Astra-G	Body	Softtop Controller																																			
Astra/Astra-G	Information	Read security PIN code																																			
Astra/Astra-G	Infortainment System	Trip Info Display																																			
Astra/Astra-G	Infortainment System	Multi Info Display																																			
Astra/Astra-H	Engine	Z 18 XE																																			
Astra/Astra-H	Engine	Z 18 XER																																			
Astra/Astra-H	Engine	Z 19 DT(Beta)	V	V																																	
Astra/Astra-H	Engine	Z 20 LEH																																			
Astra/Astra-H	Engine	Z 20 LER																																			
Astra/Astra-H	Engine	Z 22 YH																																			
Astra/Astra-H	Transmission	AF 40-6(Beta)										V																									
Astra/Astra-H	Transmission	AF 22-4																																			
Astra/Astra-H	Transmission	AF 17-4																																			
Astra/Astra-H	Chassis	ABS/TC/ESP																																			
Astra/Astra-H	Chassis	EHPS(Electrohydraulic power steering)																																			
Astra/Astra-H	Body	SDM(Airbag)																									V										
Astra/Astra-H	Body	CIM(Steering column module)																																V	V		
Astra/Astra-H	Body	IPC(Instrument control unit)																																			
Astra/Astra-H	Body	UEC(Underhood electrical centre)																																			
Astra/Astra-H	Body	REC(Rear electrical centre)																																			
Astra/Astra-H	Body	PAS(Park pilot)																																			
Astra/Astra-H	Body	SAC(Air conditioning)																															V				
Astra/Astra-H	Body	Electrohydraulic hard top																																			
Combo/Corsa-B	Engine	C 14 SE																																			
Combo/Corsa-B	Engine	Z 14 XE																																			
Combo/Corsa-B	Engine	Z 14 XEP																																			
Combo/Corsa-B	Engine	Z 16 SE																																			
Combo/Corsa-B	Engine	Z 18 XE																																			
Combo/Corsa-B	Transmission	AF 13/14/20																																			
Combo/Corsa-B	Transmission	AF 13II/20/22/30									V																										
Combo/Corsa-B	Transmission	AF 13-II/17/20/22 CAN																																			
Combo/Corsa-B	Chassis	ABS 5.3/5.4 +TC																																			
Combo/Corsa-B	Chassis	ABS/ESP8																																			
Combo/Corsa-B	Chassis	Electronic Power Steering																																			
Combo/Corsa-B	Body	Immobiliser																V	V	V	V	V	V														

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
Combo/Corsa-B	Body	Body Control Module																																V			
Combo/Corsa-B	Body	SRS Airbag																										V	V	V							
Combo/Corsa-B	Body	Instrument																														V					
Combo/Corsa-B	Information	Trip info display																																			
Combo/Corsa-C	Engine	Z 14 XE																																			
Combo/Corsa-C	Engine	Z 14 XEP																																			
Combo/Corsa-C	Engine	Z 16 SE																																			
Combo/Corsa-C	Engine	Z 18 XE																																			
Combo/Corsa-C	Transmission	AF 13-II/17/20/22 CAN																																			
Combo/Corsa-C	Chassis	ABS 5.3/5.4 +TC																																			
Combo/Corsa-C	Chassis	Electronic Power Steering																																			
Combo/Corsa-C	Body	Immobiliser																V	V	V	V	V	V														
Combo/Corsa-C	Body	Body Control Module																																V			
Combo/Corsa-C	Body	SRS Airbag																										V	V	V							
Combo/Corsa-C	Body	Instrument																														V					
Combo/Corsa-C	Information	Read security PIN code																																			
Trax		Engine Control Module 1.4L - 2WD																																			
Trax		Engine Control Module 1.4L - AWD																																			
Trax		Engine Control Module 1.8L - 2WD																																			
Trax		Engine Control Module 1.8L - AWD																																			
Trax		Engine Control Module 1.7L																																			
Trax		Transmission																																			
Trax		Rear Differential Clutch Control Module - Beta																																			
Trax		EBCM(Electronic brake control module)																																			
Trax		PSCM(Power steering control module)																																			
Trax		SWASM(Steering wheel angle sensor module)																																			
Trax		Immobilizer																																			
Trax		BCM(Body control module)																																			
Trax		SDM(Inflatable restraint sensing and diagnostic module)																																			
Trax		IC(Instrument cluster)																																			
Trax		Radio																																			
Trax		HVAC(Heating Ventilating and Air Conditioning)																																			
Trax		SHCM(Seat heating control module)																																			
Trax		PACM(Parking assist control module)																																			
Jackaroo/Monterey	Engine	6VD1																																			
Jackaroo/Monterey	Engine	3.0 L4 4JX1					V	V																													
Jackaroo/Monterey	Engine	3.2 V6 6VD1 Hitachi																																			
Jackaroo/Monterey	Engine	3.5 V6 6VE1 Hitachi																																			

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
Jackaroo/Monterey	Transmission	4L30E																																		
Jackaroo/Monterey	Transmission	AW30-40LE																																		
Jackaroo/Monterey	Body	Immobilizer																V																		
Jackaroo/Monterey	Body	Airbag																																		
Jackaroo/Monterey	Body	Aniti theft warning																																		
Rodeo/Colorado/Rodeo	Engine	6VD1																																		
Rodeo/Colorado/Rodeo	Engine	2.2 L4 SOHC																																		
Rodeo/Colorado/Rodeo	Engine	2.X L4 HV240																																		
Rodeo/Colorado/Rodeo	Engine	3.2 V6 6VD1 Hitachi																																		
Rodeo/Colorado/Rodeo	Transmission	4L30E																																		
Rodeo/Colorado/Rodeo	Transmission	AW30-40LE																																		
Rodeo/Colorado/Rodeo	Body	Immobilizer																V						V	V											
Rodeo/Colorado/Rodeo	Body	Aniti theft warning																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.2 L4 SOHC																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.4 LP1 EURO3																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	2.X L4 HV240																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.0 iTD(4JH1-TC)																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	3.5 V6 6VE1 Hitachi																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Engine	V6 Engine				V																														
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AT JR405E																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	AW30-40LE																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Transmission	Auto transmission																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Chassis	ABS																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Immobilizer																V						V	V											
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	PIM(Powertrain interface module)																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	SRS airbag																																		
Rodeo/Colorado/RA Rodeo(Up to 2007)	Body	Aniti theft warning																																		
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	2.4 LP1 EURO3																																		
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Delphi)							V	V																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	4JJ1-TC(Transtron)							V	V																										
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Engine	V6 Engine				V																														
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Chassis	ABS																																		
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	AW30-40LE																																		
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Transmission	Auto transmission																																		
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Immobilizer(V6 Engine)																V						V	V											
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	SRS(Airbag)																																		
Rodeo/Colorado/RA Rodeo/Colorado(From 2007)	Body	Aniti theft warning																																		
New Colorado/Colorado7	Engine	2.8L Diesel(LWH)																																		

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU4																																			
New Colorado/Colorado7	Engine	2.8L Diesel(LWN) -EU5																																			
New Colorado/Colorado7	Chassis	Electronic brake control module																																			
New Colorado/Colorado7	Chassis	Transfer case control module																																			
New Colorado/Colorado7	Chassis	Steering wheel angle sensor module																																			
New Colorado/Colorado7	Chassis	Multi-Axis acceleration sensor module																																			
New Colorado/Colorado7	Transmission	Auto transmission(6SP)																																			
New Colorado/Colorado7	Body	Immobilizer(New Colorado)																																			
New Colorado/Colorado7	Body	Body Control Module																																			
New Colorado/Colorado7	Body	Instrument cluster																																			
New Colorado/Colorado7	Body	SRS(Airbag)																																			
Tigra/Tigra-B	Engine	C 14 SE																																			
Tigra/Tigra-B	Engine	Z 14 XE																																			
Tigra/Tigra-B	Engine	Z 14 XEP																																			
Tigra/Tigra-B	Engine	Z 16 SE																																			
Tigra/Tigra-B	Engine	Z 18 XE																																			
Tigra/Tigra-B	Transmission	AF 13/14/20																																			
Tigra/Tigra-B	Transmission	AF 13II/20/22/30									V																										
Tigra/Tigra-B	Transmission	AF 13-II/17/20/22 CAN																																			
Tigra/Tigra-B	Chassis	ABS 5.3/5.4 +TC																																			
Tigra/Tigra-B	Chassis	ABS/ESP8																																			
Tigra/Tigra-B	Chassis	Electronic Power Steering																																			
Tigra/Tigra-B	Body	Immobiliser																V	V	V	V	V	V														
Tigra/Tigra-B	Body	Body Control Module																																V			
Tigra/Tigra-B	Body	SRS Airbag																										V	V	V							
Tigra/Tigra-B	Body	Instrument																														V					
Tigra/Tigra-B	Information	Read security PIN code																																			
Tigra/Tigra-B	Information	Trip info display																																			
Vectra/Vectra-B	Engine	C 20 SEL																																			
Vectra/Vectra-B	Engine	C 22 SEL																																			
Vectra/Vectra-B	Engine	Z 22 SE																																			
Vectra/Vectra-B	Engine	X 25 XE																																			
Vectra/Vectra-B	Engine	Y 26 SE																																			
Vectra/Vectra-B	Transmission	AF 13/14/20																																			
Vectra/Vectra-B	Transmission	AF 13II/20/22/30									V																										
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22									V																										
Vectra/Vectra-B	Transmission	AF 13-II/17/20/22 CAN																																			
Vectra/Vectra-B	Chassis	ABS 5.3/5.4 +TC																																			

Model	Group	System	Replace Diesel particulate filter	Replace recatalyst	Program Idle Speed	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	Injector ID Code Read	Supply Pump Initializtion	Reset TC signal status	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Program Transponder key	Erase transponder keys	Program mechanical key number	Program transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Program transponder keys	Clear deployment record	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Program seat belt remainder	Reset service interval	Calibration step motor	Reset body control module	Erase transponder/Remote key	Program transponder/Remote key	Reset seat endpositions
Vectra/Vectra-B	Body	Immobiliser																V	V	V	V	V	V														
Vectra/Vectra-B	Body	SRS Airbag SAB6																																			
Vectra/Vectra-B	Body	Central Door Lock																																			
Vectra/Vectra-B	Body	Instrument																																			
Vectra/Vectra-B	Information	Read security PIN code																																			
Vectra/Vectra-B	Infotainment System	Trip info display																																			
Vectra/Vectra-C	Engine	Z 32 SE																																			
Vectra/Vectra-C	Transmission	AF 23-5/33-5/40-6																																			
Vectra/Vectra-C	Chassis	ABS/TC/ESP																																			
Vectra/Vectra-C	Chassis	EHPS(Electrohydraulic power steering)																																			
Vectra/Vectra-C	Body	SDM(Airbag)																									V				V						
Vectra/Vectra-C	Body	CIM(Steering column module)																																V	V		
Vectra/Vectra-C	Body	BCM(Body control module)																																			
Vectra/Vectra-C	Body	IPC(Instrument control unit)																																			
Vectra/Vectra-C	Body	REC(Rear electrical control)																																			
Vectra/Vectra-C	Body	UEC(Underhood electrical control)																																			
Vectra/Vectra-C	Body	DDM(Driver door module)																																			
Vectra/Vectra-C	Body	PDM(Passenger door module)																																			
Vectra/Vectra-C	Body	SLM(Shift lever module)																																			
Vectra/Vectra-C	Body	Electronic seat																																			V
Vectra/Vectra-C	Information	Read security PIN code																																			
Zafira/2001-2005	Engine	Z 22 SE																																			
Zafira/2001-2005	Transmission	AF 13-II/17/20/22 CAN																																			
Zafira/2001-2005	Chassis	ABS 5.3/5.4 +TC																																			
Zafira/2001-2005	Chassis	Electronic Power Steering																																			
Zafira/2001-2005	Body	Immobiliser																V	V	V	V	V	V														
Zafira/2001-2005	Body	SRS Airbag																																			
Zafira/2001-2005	Body	Instrument																														V					
Zafira/2001-2005	Body	Engine Cooling Module																																			
Zafira/2001-2005	Body	Central Door Lock																																			
Zafira/2001-2005	Information	Read security PIN code																																			
Zafira/2001-2005	Infortainment System	Trip Info Display																																			

Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	ECU Reset	SCS Short Mode	ALL SENSORS	VSA SENSOR NEUTRAL POSITION MEMORIZATION	VSA SENS NEUTRAL POS MEM (Manual	Torque Sensor Learn	REWRITE KEYS	ALL KEYS LOST	REWRITE KEYS	ALL KEYS LOST	System Check	Number of Key	Key Type	Keyless Transmitter Registration	IQA Data Status	IQA Data Write	DPF Regeneration	DPF Differential Pressure Sensor Initial Learn	Reset Calculated PM Value	CRANK (CKP PATTERN CLEAR	CRANK (CKP PATTERN LEARNING	CRANK (CKP PATTERN CLEAR	CRANK (CKP PATTERN LEARNING	TP Position Check (TP learning Value Reset	FUEL PUMP ON TEST	ONE INJECTOR	ALL INJECTORS	A/C CLUTCH TEST	OPDS Initialization	Power Window Reset for Driver side	Power Window Reset for Passenger side	Power Window Reset for Left Rear	Power Window Reset for Right Rear	EGR test	Cruise Control Cancel History	ETCS (TAC TEST	FUEL PUMP OFF TEST	Shift Solenoid A Test	Shift Solenoid B Test
16PIN CONNECTOR	SYSTEM SEARCH																																													
16PIN CONNECTOR	Engine		V	V	V		V	V																		V	V	V	V	V	V	V	V	V						V	V	V	V		
16PIN CONNECTOR	Diesel		V		V		V	V													V	V	V	V	V									V											
16PIN CONNECTOR	AT/CVT		V	V	V		V	V																																					V	V
16PIN CONNECTOR	ABS(Antilocked Braking System)	ABS(Antilocked Braking System)	V		V	V	V																																						
16PIN CONNECTOR	ABS(Antilocked Braking System)	VSA(Vehicle Stability Assist)	V		V	V	V			V	V	V																																	
16PIN CONNECTOR	SRS Airbag		V		V		V																												V										
16PIN CONNECTOR	Immobilizer/One Push Start																																												
16PIN CONNECTOR	Immobilizer/One Push Start	PCU	V		V		V																																						
16PIN CONNECTOR	Immobilizer/One Push Start	Registration																																											
16PIN CONNECTOR	Immobilizer/One Push Start	Backup Unit	V		V		V																																						
16PIN CONNECTOR	Immobilizer/One Push Start	SLOT Control Unit	V		V		V																																						
16PIN CONNECTOR	Immobilizer/One Push Start	Control Unit	V		V		V																																						
16PIN CONNECTOR	Immobilizer/One Push Start													V	V	V	V	V	V	V	V																								
16PIN CONNECTOR	IMA		V				V																																						
16PIN CONNECTOR	ACM		V				V																																						
16PIN CONNECTOR	EPS		V		V		V						V																																
16PIN CONNECTOR	SH-AWD		V		V		V																																						
16PIN CONNECTOR	VTM 4		V				V																																						
16PIN CONNECTOR	AWD		V		V		V																																						
16PIN CONNECTOR	City-Brake Active System		V		V		V																																						
16PIN CONNECTOR	Electronic Servo Brake System		V		V		V																																						
16PIN CONNECTOR	Acoustic Vehicle Alerting System		V		V		V																																						
16PIN CONNECTOR	CAN Gateway		V				V																																						
16PIN CONNECTOR	Integrated Driver Support System		V				V																																						
16PIN CONNECTOR	Active Damper		V																																										
16PIN CONNECTOR	POP-UP HOOD		V		V		V																																						
16PIN CONNECTOR	TPMS		V		V		V																																						
16PIN CONNECTOR	EVPS		V					V																																					
16PIN CONNECTOR	BODY	GAUGE	V		V		V																																						
16PIN CONNECTOR	BODY	LIGHTING	V		V	V																																							

Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	ECU Reset	SCS Short Mode	ALL SENSORS	VSA SENSOR NEUTRAL POSITION MEMORIZATION	VSA SENS NEUTRAL POS MEM (Manual	Torque Sensor Learn	REWRITE KEYS	ALL KEYS LOST	REWRITE KEYS	ALL KEYS LOST	System Check	Number of Key	Key Type	Keyless Transmitter Registration	IQA Data Status	IQA Data Write	DPF Regeneration	DPF Differential Pressure Sensor Initial Learn	Reset Calculated PM Value	CRANK (CKP PATTERN CLEAR	CRANK (CKP PATTERN LEARNING	CRANK (CKP PATTERN CLEAR	CRANK (CKP PATTERN LEARNING	TP Position Check (TP learning Value Reset	FUEL PUMP ON TEST	ONE INJECTOR	ALL INJECTORS	A/C CLUTCH TEST	OPDS Initialization	Power Window Reset for Driver side	Power Window Reset for Passenger side	Power Window Reset for Left Rear	Power Window Reset for Right Rear	EGR test	Cruise Control Cancel History	ETCS (TAC TEST	FUEL PUMP OFF TEST	Shift Solenoid A Test	Shift Solenoid B Test
16PIN CONNECTOR	BODY	DOOR LOCKS	V		V	V																																									
16PIN CONNECTOR	BODY	KEYLESS TRANSMITTER	V		V																																										
16PIN CONNECTOR	BODY	POWER WINDOWS	V		V																															V	V	V	V								
16PIN CONNECTOR	BODY	WIPER	V		V	V																																									
16PIN CONNECTOR	BODY	SECURITY	V		V																																										
16PIN CONNECTOR	BODY	HVAC/CLIMATE CONTROL	V		V																																										
16PIN CONNECTOR	BODY	POWER TRUNK	V		V	V																																									
16PIN CONNECTOR	BODY	POWER SEAT/MIRROR	V		V	V																																									
16PIN CONNECTOR	BODY	ADAPTIVE FRONT LIGHTING	V		V																																										
16PIN CONNECTOR	BODY	AUTO LIGHT LEVELING	V		V																																										
16PIN CONNECTOR	BODY	POWER TAIL GATE	V		V	V																																									
16PIN CONNECTOR	BODY	OnStar	V		V																																										
16PIN CONNECTOR	BODY	High Beam Support	V		V																																										
16PIN CONNECTOR	BODY	Active Cornering Light	V		V																																										
16PIN CONNECTOR	BODY	Parking_Sensor	V		V																																										
16PIN CONNECTOR	BODY	HF LINK TEL	V		V																																										
16PIN CONNECTOR	BODY	Power Sliding Door	V		V	V																																									
16PIN CONNECTOR	SCS SHORT MODE								V																																						
3PIN CONNECTOR	SYSTEM SEARCH																																														
3PIN CONNECTOR	Engine		V		V		V	V																																							
3PIN CONNECTOR	AT		V		V		V	V																																							
3PIN CONNECTOR	CVT		V		V		V	V																																							
3PIN CONNECTOR	ABS(Antilocked Braking System)	ABS(Antilocked Braking System)	V		V	V	V																																							
3PIN CONNECTOR	ABS(Antilocked Braking System)	VSA(Vehicle Stability Assist)	V		V	V	V																																							
3PIN CONNECTOR	SRS Airbag		V		V																																										

Year	System 1	System 2	Shift Solenoid C Test	Shift Solenoid D Test	Shift Solenoid E Test	Pressure Test Assistance Mode	Shift Lock Solenoid Test	Clutch Pressure Control Solenoid Valve Control	Clutch Pressure Control (Linear Solenoid Valve A Test	Clutch Pressure Control (Linear Solenoid Valve B Test	Clutch Pressure Control (Linear Solenoid Valve C Test	Clutch Pressure Control (Linear Solenoid Valve D Test	Shift Solenoid Test	Acceleration Device Test	Clutch Coil Test	Differential Torque Calibration	YAW Rate/Lateral Acceleration Sensor Calibration	Steering Angle Sensor Calibration	SH-AWD Initialization	All Sensor Calibration	Seat Output Check	SWS Initialization	Inhibitor Solenoid	Shift Lock Solenoid Test	Start Clutch Status Data Clear	Start Clutch Status Feedback Learn	ACM Reset	VTC Test	EGR Test	Injector Test	Fuel Heater ON/OFF	ACG ON/OFF	Glow ON/OFF	MAF Sensor Learning Clear	A/F Sensor Learning Clear	ISV Forced Learning	Keyless Check	History Data	History Data Clear	Initialization	Service Reminder (USA	PAX Warning Reset (USA	ODS Initialization	Add A KEYLESS ACCESS Remote	Rewrite KEYLESS ACCESS Remotes	All KEYLESS ACCESS Remotes Lost
16PIN CONNECTOR	SYSTEM SEARCH																																														
16PIN CONNECTOR	Engine																											V	V																		
16PIN CONNECTOR	Diesel																													V	V	V	V	V	V	V											
16PIN CONNECTOR	AT/CVT		V	V	V	V	V	V	V	V	V	V											V	V	V	V																					
16PIN CONNECTOR	ABS(Antilocked Braking System)	ABS(Antilocked Braking System)																																													
16PIN CONNECTOR	ABS(Antilocked Braking System)	VSA(Vehicle Stability Assist)																																													
16PIN CONNECTOR	SRS Airbag																				V	V																						V			
16PIN CONNECTOR	Immobilizer/One Push Start																																														
16PIN CONNECTOR	Immobilizer/One Push Start	PCU																																													
16PIN CONNECTOR	Immobilizer/One Push Start	Registration																																										V	V	V
16PIN CONNECTOR	Immobilizer/One Push Start	Backup Unit																																													
16PIN CONNECTOR	Immobilizer/One Push Start	SLOT Control Unit																																													
16PIN CONNECTOR	Immobilizer/One Push Start	Control Unit																																													
16PIN CONNECTOR	Immobilizer/One Push Start																																														
16PIN CONNECTOR	IMA																																														
16PIN CONNECTOR	ACM																										V																				
16PIN CONNECTOR	EPS																																														
16PIN CONNECTOR	SH-AWD												V	V	V	V	V	V	V	V																											
16PIN CONNECTOR	VTM 4																																							V							
16PIN CONNECTOR	AWD																																														
16PIN CONNECTOR	City-Brake Active System																																														
16PIN CONNECTOR	Electronic Servo Brake System																																														
16PIN CONNECTOR	Acoustic Vehicle Alerting System																																														
16PIN CONNECTOR	CAN Gateway																																														
16PIN CONNECTOR	Integrated Driver Support System																																														
16PIN CONNECTOR	Active Damper																																														
16PIN CONNECTOR	POP-UP HOOD																																														
16PIN CONNECTOR	TPMS																																														
16PIN CONNECTOR	EVPS																																														
16PIN CONNECTOR	BODY	GAUGE																																													
16PIN CONNECTOR	BODY	LIGHTING																																													

Year	System 1	System 2	Shift Solenoid C Test	Shift Solenoid D Test	Shift Solenoid E Test	Pressure Test Assistance Mode	Shift Lock Solenoid Test	Clutch Pressure Control Solenoid Valve Control	Clutch Pressure Control (Linear Solenoid Valve A Test	Clutch Pressure Control (Linear Solenoid Valve B Test	Clutch Pressure Control (Linear Solenoid Valve C Test	Clutch Pressure Control (Linear Solenoid Valve D Test	Shift Solenoid Test	Acceleration Device Test	Clutch Coil Test	Differential Torque Calibration	YAW Rate/Lateral Acceleration Sensor Calibration	Steering Angle Sensor Calibration	SH-AWD Initialization	All Sensor Calibration	Seat Output Check	SWS Initialization	Inhibitor Solenoid	Shift Lock Solenoid Test	Start Clutch Status Data Clear	Start Clutch Status Feedback Learn	ACM Reset	VTC Test	EGR Test	Injector Test	Fuel Heater ON/OFF	ACG ON/OFF	Glow ON/OFF	MAF Sensor Learning Clear	A/F Sensor Learning Clear	ISV Forced Learning	Keyless Check	History Data	History Data Clear	Initialization	Service Reminder (USA	PAX Warning Reset (USA	ODS Initialization	Add A KEYLESS ACCESS Remote	Rewrite KEYLESS ACCESS Remotes	All KEYLESS ACCESS Remotes Lost
16PIN CONNECTOR	BODY	DOOR LOCKS																																													
16PIN CONNECTOR	BODY	KEYLESS TRANSMITTER																																		V										
16PIN CONNECTOR	BODY	POWER WINDOWS																																													
16PIN CONNECTOR	BODY	WIPER																																													
16PIN CONNECTOR	BODY	SECURITY																																													
16PIN CONNECTOR	BODY	HVAC/CLIMATE CONTROL																																													
16PIN CONNECTOR	BODY	POWER TRUNK																																													
16PIN CONNECTOR	BODY	POWER SEAT/MIRROR																																													
16PIN CONNECTOR	BODY	ADAPTIVE FRONT LIGHTING																																													
16PIN CONNECTOR	BODY	AUTO LIGHT LEVELING																																													
16PIN CONNECTOR	BODY	POWER TAIL GATE																																													
16PIN CONNECTOR	BODY	OnStar																																													
16PIN CONNECTOR	BODY	High Beam Support																																													
16PIN CONNECTOR	BODY	Active Cornering Light																																													
16PIN CONNECTOR	BODY	Parking_Sensor																																													
16PIN CONNECTOR	BODY	HF LINK TEL																																													
16PIN CONNECTOR	BODY	Power Sliding Door																																													
16PIN CONNECTOR	SCS SHORT MODE																																														
3PIN CONNECTOR	SYSTEM SEARCH																																														
3PIN CONNECTOR	Engine																																														
3PIN CONNECTOR	AT																																														
3PIN CONNECTOR	CVT																																														
3PIN CONNECTOR	ABS(Antilocked Braking System)	ABS(Antilocked Braking System)																																													
3PIN CONNECTOR	ABS(Antilocked Braking System)	VSA(Vehicle Stability Assist)																																													
3PIN CONNECTOR	SRS Airbag																																														

Year	System 1	System 2	Self Check	System Check	Number of KEYLESS ACCESS Remotes)	Sensor ID Learning	VTEC TEST	Modulator Bleed	Front ACM Solenoid ON/OFF	Rear ACM Solenoid ON/OFF	Front/Rear ACM Solenoid ON/OFF	Warning Display Force Activation	Vehicle Level Position Calibration	Self Check	History Data	Functional Tests	Customize Rese	Air Bleeding	Longitudinal G Sensor Learning	Left Front Solenoid Test	Right Front Solenoid Test	Left Rear Solenoid Test	Right Rear Solenoid Test	Left Front VSA Test	Right Front VSA Test	Left Rear VSA Test	Right Rear VSA Test	Left Front CAS Regulator Valve Test	Right Front CAS Regulator Valve Test	Left Rear CAS Regulator Valve Test	Right Rear CAS Regulator Valve Test	System Information	Parameter Information	Motor Rotor Position Calibration	IPU Module Fan Drive Test	HVAC_Climate Control Unit Self Test	Idle Stop Starter Counter Check	Warning Indicators	ECU Clear	Cell Voltage Sensor Check	Initiator Operation Check	Sensor ID Learning	MA - EPS Control ON / OFF	Radar Aiming	Static Camera Aiming
16PIN CONNECTOR	SYSTEM SEARCH																																												
16PIN CONNECTOR	Engine						V																													V								
16PIN CONNECTOR	Diesel																																												
16PIN CONNECTOR	AT/CVT																																												
16PIN CONNECTOR	ABS(Antilocked Braking System)	ABS(Antilocked Braking System)																		V	V	V	V																						
16PIN CONNECTOR	ABS(Antilocked Braking System)	VSA(Vehicle Stability Assist)						V												V	V	V	V	V	V	V	V	V	V	V	V														
16PIN CONNECTOR	SRS Airbag																															V	V												
16PIN CONNECTOR	Immobilizer/One Push Start																																												
16PIN CONNECTOR	Immobilizer/One Push Start	PCU												V	V																														
16PIN CONNECTOR	Immobilizer/One Push Start	Registration																																											
16PIN CONNECTOR	Immobilizer/One Push Start	Backup Unit	V	V	V																																								
16PIN CONNECTOR	Immobilizer/One Push Start	SLOT Control Unit																																											
16PIN CONNECTOR	Immobilizer/One Push Start	Control Unit																																											
16PIN CONNECTOR	Immobilizer/One Push Start																																												
16PIN CONNECTOR	IMA																																												
16PIN CONNECTOR	ACM								V	V	V																																		
16PIN CONNECTOR	EPS																																										V		
16PIN CONNECTOR	SH-AWD																																												
16PIN CONNECTOR	VTM 4																																												
16PIN CONNECTOR	AWD																	V	V																										
16PIN CONNECTOR	City-Brake Active System																																												
16PIN CONNECTOR	Electronic Servo Brake System																																												
16PIN CONNECTOR	Acoustic Vehicle Alerting System																																												
16PIN CONNECTOR	CAN Gateway																																												
16PIN CONNECTOR	Integrated Driver Support System																																											V	V
16PIN CONNECTOR	Active Damper																																												
16PIN CONNECTOR	POP-UP HOOD											V	V																																
16PIN CONNECTOR	TPMS					V																															V			V	V				
16PIN CONNECTOR	EVPS																																												
16PIN CONNECTOR	BODY	GAUGE														V	V																												
16PIN CONNECTOR	BODY	LIGHTING																																											

Year	System 1	System 2	Self Check	System Check	Number of KEYLESS ACCESS Remotes)	Sensor ID Learning	VTEC TEST	Modulator Bleed	Front ACM Solenoid ON/OFF	Rear ACM Solenoid ON/OFF	Front/Rear ACM Solenoid ON/OFF	Warning Display Force Activation	Vehicle Level Position Calibration	Self Check	History Data	Functional Tests	Customize Rese	Air Bleeding	Longitudinal G Sensor Learning	Left Front Solenoid Test	Right Front Solenoid Test	Left Rear Solenoid Test	Right Rear Solenoid Test	Left Front VSA Test	Right Front VSA Test	Left Rear VSA Test	Right Rear VSA Test	Left Front CAS Regulator Valve Test	Right Front CAS Regulator Valve Test	Left Rear CAS Regulator Valve Test	Right Rear CAS Regulator Valve Test	System Information	Parameter Information	Motor Rotor Position Calibration	IPU Module Fan Drive Test	HVAC_Climate Control Unit Self Test	Idle Stop Starter Counter Check	Warning Indicators	ECU Clear	Cell Voltage Sensor Check	Initiator Operation Check	Sensor ID Learning	MA - EPS Control ON / OFF	Radar Aiming	Static Camera Aiming
16PIN CONNECTOR	BODY	DOOR LOCKS																																											
16PIN CONNECTOR	BODY	KEYLESS TRANSMITTER																																											
16PIN CONNECTOR	BODY	POWER WINDOWS																																											
16PIN CONNECTOR	BODY	WIPER																																											
16PIN CONNECTOR	BODY	SECURITY																																											
16PIN CONNECTOR	BODY	HVAC/CLIMATE CONTROL																																	V										
16PIN CONNECTOR	BODY	POWER TRUNK																																											
16PIN CONNECTOR	BODY	POWER SEAT/MIRROR																																											
16PIN CONNECTOR	BODY	ADAPTIVE FRONT LIGHTING																																											
16PIN CONNECTOR	BODY	AUTO LIGHT LEVELING																																											
16PIN CONNECTOR	BODY	POWER TAIL GATE																																											
16PIN CONNECTOR	BODY	OnStar																																											
16PIN CONNECTOR	BODY	High Beam Support																																											
16PIN CONNECTOR	BODY	Active Cornering Light																																											
16PIN CONNECTOR	BODY	Parking_Sensor																																											
16PIN CONNECTOR	BODY	HF LINK TEL																																											
16PIN CONNECTOR	BODY	Power Sliding Door																																											
16PIN CONNECTOR	SCS SHORT MODE																																												
3PIN CONNECTOR	SYSTEM SEARCH																																												
3PIN CONNECTOR	Engine																																												
3PIN CONNECTOR	AT																																												
3PIN CONNECTOR	CVT																																												
3PIN CONNECTOR	ABS(Antilocked Braking System)	ABS(Antilocked Braking System)																																											
3PIN CONNECTOR	ABS(Antilocked Braking System)	VSA(Vehicle Stability Assist)																																											
3PIN CONNECTOR	SRS Airbag																																												

Vehicle	System 1	System 2	DTC	CURR	ACT	ECU Information Display	Configuration	ECU Reset	ECU Learning	ICU Learning	Keys Learning	Immo Reset	Keys Reset	ECU,ISU,Key Learning	Engine immobiliser code and key	ECM ICU and Key Learning	ECM Neutralizing	ICU Neutralizing	Status Reading	Initialising the autoadaptives	Adaptive value reseting	Cruise Control Activation	Setting of CNG tanks	Bleeding	Remote Learning	Auto Configuration	Adjust Emission Control	TEVES MK20 Bleeding	TEVES MK20 Simulation	AT Initialising the autoadaptive	Oil wear counter	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Sun roof Configuration	Alarm Configuration	VIN code	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration
Peugeot 206	Built-In system interface	Built-In system interface	V	V	V	V																																					
Peugeot 206	Engine	KFW SAGEM S2000	V	V	V	V	V													V						V																	
Peugeot 206	Engine	K6D SAGEM S2000	V	V	V	V	V													V						V																	
Peugeot 206	Engine	N6A BOSCH ME7.4.4	V	V	V	V	V													V						V																	
Peugeot 206	Engine	NFU BOSCH ME7.4.4	V	V	V	V	V													V						V																	
Peugeot 206	Engine	KFW BOSCH ME7.4.4	V	V	V	V	V													V						V																	
Peugeot 206	Engine	N6A BOSCH ME7.4.5	V	V	V	V	V													V						V																	
Peugeot 206	Engine	NFU BOSCH ME7.4.5	V	V	V	V	V													V						V																	
Peugeot 206	Engine	KFW J34P (Valeo)	V	V	V	V	V													V						V																	
Peugeot 206	Engine	NFU J35P (Valeo)	V	V	V	V	V													V																							
Peugeot 206	Automatic Transaxle	AL4 automatic gearbox	V	V	V	V																								V	V												
Peugeot 206	Alarm	Alarm	V		V	V																																V					
Peugeot 206	Driver information / Communication	Display/Telematics (AMF)	V	V	V	V																																					
Peugeot 206	Driver information / Communication	Display/Telematics (RT3)	V	V	V	V																																					
Peugeot 206	Driver information / Communication	Radio	V	V	V	V																																	V	V			
Peugeot 206	Driver information / Communication	CD Player	V	V	V	V																																			V		
Peugeot 206	Driver information / Communication	Instrument panel	V	V	V	V																																				V	
Peugeot 206	Driver information / Communication	Switching module steering wheel	V	V		V																																					
Peugeot 206	Driver information / Communication	On-board navigation system	V	V		V																																					
Peugeot 206	Visibility/Lighting	Driving school		V	V	V																																					
Peugeot 206	Visibility/Lighting	Rain/sunlight sensor	V			V																																					
Peugeot 206	Airbag	Airbag SAC Central	V	V		V																																					V
Peugeot 206	Control the openings	Electric retractable roof	V	V	V	V																														V							
Peugeot 206	Heating/ventilation	A/C	V	V	V	V																																					
Peugeot 206	Active Safety	ABS TEVES MK20	V	V	V	V																						V	V														
Peugeot 206	Active Safety	ABS TEVES MK70	V	V	V	V																										V	V	V	V	V							
Peugeot 206	Active Safety	ESP TEVES MK60	V	V	V	V																																					
Peugeot 206	Replacement	SAGEM S2000	V			V																																					
Peugeot 206	Replacement	BOSCH ME7.4.4	V			V																																					
Peugeot 206	Replacement	BOSCH ME7.4.5	V			V																																					
Peugeot 206	Replacement	J34P(Valeo)	V			V																																					
Peugeot 206	Downloading	Built-In system interface	V			V																																					
Peugeot 206	Downloading	J34P	V			V																																					
Peugeot 207	Engine	K6D SAGEM S2000	V	V	V	V	V													V						V																	
Peugeot 207	Engine	N6A BOSCH ME7.4.4	V	V	V	V	V													V						V																	
Peugeot 207	Engine	NFU BOSCH ME7.4.4	V	V	V	V	V													V						V																	
Peugeot 207	Engine	NFU BOSCH ME7.4.5	V	V	V	V	V													V						V																	
Peugeot 207	Engine	KFW J34P (Valeo)	V	V	V	V	V													V						V																	
Peugeot 207	Engine	NFU J35P (Valeo)	V	V	V	V	V													V																							
Peugeot 207	Automatic Transaxle	AL4 automatic gearbox	V	V	V	V																								V	V												
Peugeot 207	Alarm	Alarm	V		V	V																																V					

Vehicle	System 1	System 2	DTC	CURR	ACT	ECU Information Display	Configuration	ECU Reset	ECU Learning	ICU Learning	Keys Learning	Immo Reset	Keys Reset	ECU,ISU,Key Learning	Engine immobiliser code and key	ECM ICU and Key Learning	ECM Neutralizing	ICU Neutralizing	Status Reading	Initialising the autoadaptives	Adaptive value reseting	Cruise Control Activation	Setting of CNG tanks	Bleeding	Remote Learning	Auto Configuration	Adjust Emission Control	TEVES MK20 Bleeding	TEVES MK20 Simulation	AT Initialising the autoadaptive	Oil wear counter	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Sun roof Configuration	Alarm Configuration	VIN code	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration
Peugeot 207	Driver information / Communication	Display/Telematics (AMF)	V																																								
Peugeot 207	Driver information / Communication	Display/Telematics (RT3)	V	V	V	V																																					
Peugeot 207	Driver information / Communication	Radio	V	V	V	V																																	V	V			
Peugeot 207	Driver information / Communication	CD Player	V	V	V	V																																			V		
Peugeot 207	Driver information / Communication	Instrument panel	V	V	V	V																																				V	
Peugeot 207	Driver information / Communication	Switching module steering wheel	V	V		V																																					
Peugeot 207	Driver information / Communication	On-board navigation system	V	V		V																																					
Peugeot 207	Visibility/Lighting	Driving school		V	V	V																																					
Peugeot 207	Visibility/Lighting	Rain/sunlight sensor	V			V																																					
Peugeot 207	Airbag	Airbag SAC Central	V	V		V																																					V
Peugeot 207	Control the openings	Electric retractable roof	V	V	V	V																														V							
Peugeot 207	Heating/ventilation	A/C	V	V	V	V																																					
Peugeot 207	Active Safety	ABS TEVES MK20	V	V	V	V																						V	V														
Peugeot 207	Active Safety	ABS MK70	V	V	V	V																										V	V	V	V	V							
Peugeot 207	Active Safety	ESP MK60	V	V	V	V																																					
Peugeot 207	Built-In system interface	BSI	V	V	V	V																																					
Peugeot 207	Built-In system interface	BSI Downloading	V			V																																					
Peugeot 207	Replacement	SAGEM S2000	V			V																																					
Peugeot 207	Replacement	BOSCH ME7.4.4	V			V																																					
Peugeot 207	Replacement	BOSCH ME7.4.5	V			V																																					
Peugeot 207	Replacement	J34P(Valeo)	V			V																																					
Peykan	Engine	SL96	V	V	V	V																					V																
Peykan	Engine	S2000 (11)	V	V	V	V														V																							
Peugeot ROA	Engine	SL96	V	V	V	V																					V																
Peugeot ROA	Engine	S2000 (11)	V	V	V	V														V																							
Peugeot ROA	Engine	Petrol SIEMENS (XU7)	V	V	V	V															V																						
Peugeot ROA	Engine	Bifuel SIEMENS (XU7)	V	V	V	V															V																						
Peugeot ROA	Engine	Gas SIEMENS (CNG)	V	V	V	V																																					
Peugeot ROA	ABS	MANDO MGH25 / MGH60	V	V	V	V																		V																			
Peugeot ROA	ABS	TEVES MK20	V	V	V	V																																					
Peugeot ROA	ABS	TEVES MK70	V	V	V																			V																			
Peugeot ROA	ABS	BOSCH	V	V	V	V																		V																			
Peugeot ROA	ABS	Mobis	V	V	V	V																		V																			
SAMAND	Engine	SL96	V	V	V	V																					V																
SAMAND	Engine	S2000	V	V	V	V														V																							
SAMAND	Engine	S2000 (LC)	V	V	V	V														V																							
SAMAND	Engine	Petrol SIEMENS (XU7)	V	V	V	V															V																						
SAMAND	Engine	Bosch ME7.4.4	V	V	V	V														V																							
SAMAND	Engine	Gas SIEMENS (CNG)	V	V	V	V																																					
SAMAND	Engine	Bifuel BOSCH ME7.4.9NG	V	V	V	V																																					
SAMAND	Engine	Bifuel BOSCH ME7.4.9NG Immo	V	V	V	V																V	V																				

Vehicle	System 1	System 2	DTC	CURR	ACT	ECU Information Display	Configuration	ECU Reset	ECU Learning	ICU Learning	Keys Learning	Immo Reset	Keys Reset	ECU,ISU,Key Learning	Engine immobiliser code and key	ECM ICU and Key Learning	ECM Neutralizing	ICU Neutralizing	Status Reading	Initialising the autoadaptives	Adaptive value reseting	Cruise Control Activation	Setting of CNG tanks	Bleeding	Remote Learning	Auto Configuration	Adjust Emission Control	TEVES MK20 Bleeding	TEVES MK20 Simulation	AT Initialising the autoadaptive	Oil wear counter	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Sun roof Configuration	Alarm Configuration	VIN code	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration
SAMAND	Engine	Petrol BOSCH ME7.4.9PT Immo	V	V	V	V																																					
SAMAND	Engine	OMVL	V	V	V	V																																					
SAMAND	Engine	Bosch MP7.3 (Sarir)	V	V	V	V														V																							
SAMAND	Engine	Bifuel SIEMENS (XU7)	V	V	V	V															V																						
SAMAND	Engine	Bosch ME 7.4.4 (TU5)	V	V	V	V																																					
SAMAND	Engine	Petrol SIEMENS (EF7)	V	V	V	V																																					
SAMAND	Engine	Bifuel SIEMENS (EF7)	V	V	V	V																																					
SAMAND	Engine	SIEMENS Micro Hybrid	V	V	V	V																																					
SAMAND	Engine	EF7 TC	V	V	V	V																																					
SAMAND	Engine	Bosch SSAT (XU7)	V	V	V	V																																					
SAMAND	Engine	Bifuel BOSCH ME7.4.9.NG (Euro4)	V	V	V	V																V																					
SAMAND	Engine	Petrol BOSCH ME7.4.9.PT (Euro4)	V	V	V	V																V																					
SAMAND	ABS	MANDO MGH25 / MGH60	V	V	V	V																		V																			
SAMAND	ABS	TEVES MK20	V	V	V	V																																					
SAMAND	ABS	TEVES MK70	V	V	V																			V																			
SAMAND	ABS	BOSCH	V	V	V	V																		V																			
SAMAND	ABS	Mobis	V	V	V	V																		V																			
SAMAND	AirBag	HAE 2.5	V			V																																					
SAMAND	AirBag	SRS	V	V		V																																					
SAMAND	AirBag	EIMEN	V	V		V																																					
SAMAND	AirBag	Crouse	V	V		V																																					
SAMAND	AirBag	Jin Heng	V	V		V																																					
SAMAND	Multiplex	CCN	V	V	V	V	V																																				
SAMAND	Multiplex	FN	V	V	V	V	V																																				
SAMAND	Multiplex	DDN	V	V	V	V	V																																				
SAMAND	Multiplex	PDN	V	V	V	V	V																																				
SAMAND	Multiplex	ICN			V	V	V																																				
SAMAND	EcoMux	BCM	V	V	V	V	V																		V																		
SAMAND	EcoMux	FCM	V	V	V	V	V																																				
SAMAND	EcoMux	ICN(Crouse)			V	V																																					
Peugeot 405	Engine	SL96	V	V	V	V																					V																
Peugeot 405	Engine	S2000	V	V	V	V														V																							
Peugeot 405	Engine	S2000 (LC)	V	V	V	V														V																							
Peugeot 405	Engine	OMVL	V	V	V	V																																					
Peugeot 405	Engine	SAX500	V	V	V	V																																					
Peugeot 405	Engine	CNG BOSCH M7.4.4	V	V	V	V																																					
Peugeot 405	Engine	Petrol SIEMENS (XU7)	V	V	V	V															V																						
Peugeot 405	Engine	Bifuel SIEMENS (XU7)	V	V	V	V															V																						
Peugeot 405	Engine	Petrol SIEMENS (XUM)	V	V	V	V															V																						
Peugeot 405	Engine	Bifuel BOSCH ME7.4.9NG	V	V	V	V																																					
Peugeot 405	Engine	Bifuel BOSCH ME7.4.9NG Immo	V	V	V	V																V	V																				

Vehicle	System 1	System 2	DTC	CURR	ACT	ECU Information Display	Configuration	ECU Reset	ECU Learning	ICU Learning	Keys Learning	Immo Reset	Keys Reset	ECU,ISU,Key Learning	Engine immobiliser code and key	ECM ICU and Key Learning	ECM Neutralizing	ICU Neutralizing	Status Reading	Initialising the autoadaptives	Adaptive value reseting	Cruise Control Activation	Setting of CNG tanks	Bleeding	Remote Learning	Auto Configuration	Adjust Emission Control	TEVES MK20 Bleeding	TEVES MK20 Simulation	AT Initialising the autoadaptive	Oil wear counter	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Sun roof Configuration	Alarm Configuration	VIN code	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration
Peugeot 405	Engine	Petrol BOSCH ME7.4.9PT Immo	V	V	V	V																																					
Peugeot 405	Engine	Bosch SSAT (XU7)	V	V	V	V																																					
Peugeot 405	ABS	MANDO MGH25 / MGH60	V	V	V	V																		V																			
Peugeot 405	ABS	TEVES MK20	V	V	V	V																																					
Peugeot 405	ABS	TEVES MK70	V	V	V																			V																			
Peugeot 405	ABS	BOSCH	V	V	V	V																		V																			
Peugeot 405	ABS	Mobis	V	V	V	V																		V																			
Peugeot 405	AirBag	HAE 2.5	V			V																																					
Peugeot 405	AirBag	SRS	V	V		V																																					
Peugeot 405	AirBag	EIMEN	V	V		V																																					
Peugeot 405	AirBag	Crouse	V	V		V																																					
Peugeot 405	AirBag	Jin Heng	V	V		V																																					
Peugeot Pars	Engine	SL96	V	V	V	V																					V																
Peugeot Pars	Engine	S2000	V	V	V	V														V																							
Peugeot Pars	Engine	S2000 (LC)	V	V	V	V														V																							
Peugeot Pars	Engine	BOSCH M7.4.4	V	V	V	V														V																							
Peugeot Pars	Engine	OMVL	V	V	V	V																																					
Peugeot Pars	Engine	Bosch MP7.3	V	V	V	V														V																							
Peugeot Pars	Engine	Petrol SIEMENS (XU7)	V	V	V	V															V																						
Peugeot Pars	Engine	Gas SIEMENS (CNG)	V	V	V	V																																					
Peugeot Pars	Engine	Bifuel SIEMENS (XU7)	V	V	V	V															V																						
Peugeot Pars	Engine	Bifuel BOSCH ME7.4.9NG	V	V	V	V																																					
Peugeot Pars	Engine	Bifuel BOSCH ME7.4.9NG Immo	V	V	V	V																V	V																				
Peugeot Pars	Engine	Petrol BOSCH ME7.4.9PT Immo	V	V	V	V																																					
Peugeot Pars	Engine	Petrol Siemens (XUM)	V	V	V	V															V																						
Peugeot Pars	Engine	Bosch SSAT (XU7)	V	V	V	V																																					
Peugeot Pars	ABS	MANDO MGH25 / MGH60	V	V	V	V																		V																			
Peugeot Pars	ABS	TEVES MK20	V	V	V	V																																					
Peugeot Pars	ABS	TEVES MK70	V	V	V																			V																			
Peugeot Pars	ABS	BOSCH	V	V	V	V																		V																			
Peugeot Pars	ABS	Mobis	V	V	V	V																		V																			
Peugeot Pars	AirBag	HAE 2.5	V			V																																					
Peugeot Pars	AirBag	SRS	V	V		V																																					
Peugeot Pars	AirBag	EIMEN	V	V		V																																					
Peugeot Pars	AirBag	Crouse	V	V		V																																					
Peugeot Pars	AirBag	Jin Heng	V	V		V																																					
Vanet	Engine	SL96	V	V	V	V																					V																
Vanet	Engine	S2000 (11)	V	V	V	V														V																							
Vanet	Engine	S2000 (11)	V	V	V	V														V																							
Vanet	Engine	Petrol SIEMENS (XU7)	V	V	V	V															V																						
Vanet	Engine	Bifuel Siemens (XU7)	V	V	V	V															V																						

Vehicle	System 1	System 2	DTC	CURR	ACT	ECU Information Display	Configuration	ECU Reset	ECU Learning	ICU Learning	Keys Learning	Immo Reset	Keys Reset	ECU,ISU,Key Learning	Engine immobiliser code and key	ECM ICU and Key Learning	ECM Neutralizing	ICU Neutralizing	Status Reading	Initialising the autoadaptives	Adaptive value reseting	Cruise Control Activation	Setting of CNG tanks	Bleeding	Remote Learning	Auto Configuration	Adjust Emission Control	TEVES MK20 Bleeding	TEVES MK20 Simulation	AT Initialising the autoadaptive	Oil wear counter	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Sun roof Configuration	Alarm Configuration	VIN code	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration
Vanet	Engine	Gas Siemens (CNG)	V	V	V	V																																					
Vanet	ABS	MANDO MGH25 / MGH60	V	V	V	V																		V																			
Vanet	ABS	TEVES MK20	V	V	V	V																																					
Vanet	ABS	TEVES MK70	V	V	V																			V																			
Vanet	ABS	BOSCH	V	V	V	V																		V																			
Vanet	ABS	Mobis	V	V	V	V																		V																			
RUNNA	Engine	SIEMENS TU5	V	V	V	V																																					
RUNNA	ABS	MANDO MGH25 / MGH60	V	V	V	V																		V																			
RUNNA	ABS	TEVES MK20	V	V	V	V																																					
RUNNA	ABS	TEVES MK70	V	V	V																			V																			
RUNNA	ABS	BOSCH	V	V	V	V																		V																			
RUNNA	ABS	Mobis	V	V	V	V																		V																			
RUNNA	AirBag	HAE 2.5	V			V																																					
RUNNA	AirBag	SRS	V	V		V																																					
RUNNA	AirBag	EIMEN	V	V		V																																					
RUNNA	AirBag	Crouse	V	V		V																																					
RUNNA	AirBag	Jin Heng	V	V		V																																					
RUNNA	Multiplex	CCN	V	V	V	V	V																																				
RUNNA	Multiplex	FN	V	V	V	V	V																																				
RUNNA	Multiplex	MCN	V	V	V	V																																					
RUNNA	Multiplex	ICN			V	V	V																																				
RUNNA	EcoMux	BCM	V	V	V	V	V																		V																		
RUNNA	EcoMux	FCM	V	V	V	V	V																																				
RUNNA	EcoMux	ICN(Crouse)			V	V																																					
Peugeot 206 Localize	Engine	SIEMENS TU5 (CBM)	V	V	V	V																																					
Peugeot 206 Localize	ABS	MANDO MGH25 / MGH60	V	V	V	V																		V																			
Peugeot 206 Localize	ABS	TEVES MK20	V	V	V	V																																					
Peugeot 206 Localize	ABS	TEVES MK70	V	V	V																			V																			
Peugeot 206 Localize	ABS	BOSCH	V	V	V	V																		V																			
Peugeot 206 Localize	ABS	Mobis	V	V	V	V																		V																			
Peugeot 206 Localize	AirBag	HAE 2.5	V			V																																					
Peugeot 206 Localize	AirBag	SRS	V	V		V																																					
Peugeot 206 Localize	AirBag	EIMEN	V	V		V																																					
Peugeot 206 Localize	AirBag	Crouse	V	V		V																																					
Peugeot 206 Localize	AirBag	Jin Heng	V	V		V																																					
Peugeot 206 Localize	Multiplex	CCN	V	V	V	V	V																																				
Peugeot 206 Localize	Multiplex	FN	V	V	V	V	V																																				
Peugeot 206 Localize	Multiplex	ICN			V	V	V																																				
Peugeot 206 Localize	EcoMux	BCM	V	V	V	V	V																		V																		
Peugeot 206 Localize	EcoMux	FCM	V	V	V	V	V																																				
Peugeot 206 Localize	EcoMux	ICN(Crouse)			V	V																																					

Vehicle	System 1	System 2	DTC	CURR	ACT	ECU Information Display	Configuration	ECU Reset	ECU Learning	ICU Learning	Keys Learning	Immo Reset	Keys Reset	ECU,ISU,Key Learning	Engine immobiliser code and key	ECM ICU and Key Learning	ECM Neutralizing	ICU Neutralizing	Status Reading	Initialising the autoadaptives	Adaptive value reseting	Cruise Control Activation	Setting of CNG tanks	Bleeding	Remote Learning	Auto Configuration	Adjust Emission Control	TEVES MK20 Bleeding	TEVES MK20 Simulation	AT Initialising the autoadaptive	Oil wear counter	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Sun roof Configuration	Alarm Configuration	VIN code	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration
Dena	Engine	SL96	V	V	V	V																					V																
Dena	Engine	S2000	V	V	V	V														V																							
Dena	Engine	S2000 (LC)	V	V	V	V														V																							
Dena	Engine	Petrol SIEMENS (XU7)	V	V	V	V															V																						
Dena	Engine	Bosch ME7.4.4	V	V	V	V														V																							
Dena	Engine	Gas SIEMENS (CNG)	V	V	V	V																																					
Dena	Engine	Bifuel BOSCH ME7.4.9NG	V	V	V	V																																					
Dena	Engine	Bifuel BOSCH ME7.4.9NG Immo	V	V	V	V																V	V																				
Dena	Engine	Petrol BOSCH ME7.4.9PT Immo	V	V	V	V																																					
Dena	Engine	OMVL	V	V	V	V																																					
Dena	Engine	Bosch MP7.3 (Sarir)	V	V	V	V														V																							
Dena	Engine	Bifuel SIEMENS (XU7)	V	V	V	V															V																						
Dena	Engine	Bosch ME 7.4.4 (TU5)	V	V	V	V																																					
Dena	Engine	Petrol SIEMENS EF7	V	V	V	V																																					
Dena	Engine	Bifuel SIEMENS EF7	V	V	V	V																																					
Dena	Engine	SIEMENS Micro Hybrid	V	V	V	V																																					
Dena	Engine	EF7 TC	V	V	V	V																																					
Dena	Engine	Bosch SSAT (XU7)	V	V	V	V																																					
Dena	Engine	Bifuel BOSCH ME7.4.9.NG (Euro4)	V	V	V	V																V																					
Dena	Engine	Petrol BOSCH ME7.4.9.PT (Euro4)	V	V	V	V																V																					
Dena	ABS	MANDO MGH25 / MGH60	V	V	V	V																		V																			
Dena	ABS	TEVES MK20	V	V	V	V																																					
Dena	ABS	TEVES MK70	V	V	V																			V																			
Dena	ABS	BOSCH	V	V	V	V																		V																			
Dena	ABS	Mobis	V	V	V	V																		V																			
Dena	AirBag	HAE 2.5	V			V																																					
Dena	AirBag	SRS	V	V		V																																					
Dena	AirBag	EIMEN	V	V		V																																					
Dena	AirBag	Crouse	V	V		V																																					
Dena	AirBag	Jin Heng	V	V		V																																					
Special Function	Key Learning	SIEMENS	V	V				V	V	V	V	V	V																														
Special Function	Key Learning	VALEO							V	V	V			V																													
Special Function	Key Learning	Peugeot 206	V			V									V																												
Special Function	Key Learning	SIEMENS CIM	V													V	V	V	V																								
Special Function	Key Learning	SSAT	V	V				V	V	V	V	V	V						V																									
Special Function	ECU Reset	ECU Reset	V					V																																			

Vehicle	System 1	System 2	Airbag Lock	Airbag Unlock	A/C Configuration	BSI Downloading ver 30	BSI Downloading ver 32	BSI Downloading ver 34	BSI Downloading ver 38	BSI Downloading Ver.40	BSI Downloading Ver.42	BSI Downloading Ver.44	BSI Downloading Ver.45	Replacement	Downloading	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room
Peugeot 206	Built-In system interface	Built-In system interface																																								
Peugeot 206	Engine	KFW SAGEM S2000																																								
Peugeot 206	Engine	K6D SAGEM S2000																																								
Peugeot 206	Engine	N6A BOSCH ME7.4.4																																								
Peugeot 206	Engine	NFU BOSCH ME7.4.4																																								
Peugeot 206	Engine	KFW BOSCH ME7.4.4																																								
Peugeot 206	Engine	N6A BOSCH ME7.4.5																																								
Peugeot 206	Engine	NFU BOSCH ME7.4.5																																								
Peugeot 206	Engine	KFW J34P (Valeo)																																								
Peugeot 206	Engine	NFU J35P (Valeo)																																								
Peugeot 206	Automatic Transaxle	AL4 automatic gearbox																																								
Peugeot 206	Alarm	Alarm																																								
Peugeot 206	Driver information / Communication	Display/Telematics (AMF)																																								
Peugeot 206	Driver information / Communication	Display/Telematics (RT3)																																								
Peugeot 206	Driver information / Communication	Radio																																								
Peugeot 206	Driver information / Communication	CD Player																																								
Peugeot 206	Driver information / Communication	Instrument panel																																								
Peugeot 206	Driver information / Communication	Switching module steering wheel																																								
Peugeot 206	Driver information / Communication	On-board navigation system																																								
Peugeot 206	Visibility/Lighting	Driving school																																								
Peugeot 206	Visibility/Lighting	Rain/sunlight sensor																																								
Peugeot 206	Airbag	Airbag SAC Central	V	V																																						
Peugeot 206	Control the openings	Electric retractable roof																																								
Peugeot 206	Heating/ventilation	A/C			V																																					
Peugeot 206	Active Safety	ABS TEVES MK20																																								
Peugeot 206	Active Safety	ABS TEVES MK70																																								
Peugeot 206	Active Safety	ESP TEVES MK60																																								
Peugeot 206	Replacement	SAGEM S2000												V																												
Peugeot 206	Replacement	BOSCH ME7.4.4												V																												
Peugeot 206	Replacement	BOSCH ME7.4.5												V																												
Peugeot 206	Replacement	J34P(Valeo)												V																												
Peugeot 206	Downloading	Built-In system interface				V	V	V	V	V	V	V	V																													
Peugeot 206	Downloading	J34P													V																											
Peugeot 207	Engine	K6D SAGEM S2000																																								
Peugeot 207	Engine	N6A BOSCH ME7.4.4																																								
Peugeot 207	Engine	NFU BOSCH ME7.4.4																																								
Peugeot 207	Engine	NFU BOSCH ME7.4.5																																								
Peugeot 207	Engine	KFW J34P (Valeo)																																								
Peugeot 207	Engine	NFU J35P (Valeo)																																								
Peugeot 207	Automatic Transaxle	AL4 automatic gearbox																																								
Peugeot 207	Alarm	Alarm																																								

Vehicle	System 1	System 2	Airbag Lock	Airbag Unlock	A/C Configuration	BSI Downloading ver 30	BSI Downloading ver 32	BSI Downloading ver 34	BSI Downloading ver 38	BSI Downloading Ver.40	BSI Downloading Ver.42	BSI Downloading Ver.44	BSI Downloading Ver.45	Replacement	Downloading	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room
Peugeot 207	Driver information / Communication	Display/Telematics (AMF)																																								
Peugeot 207	Driver information / Communication	Display/Telematics (RT3)														V	V	V	V	V	V	V	V																			
Peugeot 207	Driver information / Communication	Radio																																								
Peugeot 207	Driver information / Communication	CD Player																																								
Peugeot 207	Driver information / Communication	Instrument panel																																								
Peugeot 207	Driver information / Communication	Switching module steering wheel																																								
Peugeot 207	Driver information / Communication	On-board navigation system																																								
Peugeot 207	Visibility/Lighting	Driving school																																								
Peugeot 207	Visibility/Lighting	Rain/sunlight sensor																																								
Peugeot 207	Airbag	Airbag SAC Central	V	V																																						
Peugeot 207	Control the openings	Electric retractable roof																																								
Peugeot 207	Heating/ventilation	A/C			V																																					
Peugeot 207	Active Safety	ABS TEVES MK20																																								
Peugeot 207	Active Safety	ABS MK70																																								
Peugeot 207	Active Safety	ESP MK60																																								
Peugeot 207	Built-In system interface	BSI																						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
Peugeot 207	Built-In system interface	BSI Downloading				V	V	V	V	V	V	V	V																													
Peugeot 207	Replacement	SAGEM S2000												V																												
Peugeot 207	Replacement	BOSCH ME7.4.4												V																												
Peugeot 207	Replacement	BOSCH ME7.4.5												V																												
Peugeot 207	Replacement	J34P(Valeo)												V																												
Peykan	Engine	SL96																																								
Peykan	Engine	S2000 (11)																																								
Peugeot ROA	Engine	SL96																																								
Peugeot ROA	Engine	S2000 (11)																																								
Peugeot ROA	Engine	Petrol SIEMENS (XU7)																																								
Peugeot ROA	Engine	Bifuel SIEMENS (XU7)																																								
Peugeot ROA	Engine	Gas SIEMENS (CNG)																																								
Peugeot ROA	ABS	MANDO MGH25 / MGH60																																								
Peugeot ROA	ABS	TEVES MK20																																								
Peugeot ROA	ABS	TEVES MK70																																								
Peugeot ROA	ABS	BOSCH																																								
Peugeot ROA	ABS	Mobis																																								
SAMAND	Engine	SL96																																								
SAMAND	Engine	S2000																																								
SAMAND	Engine	S2000 (LC)																																								
SAMAND	Engine	Petrol SIEMENS (XU7)																																								
SAMAND	Engine	Bosch ME7.4.4																																								
SAMAND	Engine	Gas SIEMENS (CNG)																																								
SAMAND	Engine	Bifuel BOSCH ME7.4.9NG																																								
SAMAND	Engine	Bifuel BOSCH ME7.4.9NG Immo																																								

Vehicle	System 1	System 2	Airbag Lock	Airbag Unlock	A/C Configuration	BSI Downloading ver 30	BSI Downloading ver 32	BSI Downloading ver 34	BSI Downloading ver 38	BSI Downloading Ver.40	BSI Downloading Ver.42	BSI Downloading Ver.44	BSI Downloading Ver.45	Replacement	Downloading	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room
SAMAND	Engine	Petrol BOSCH ME7.4.9PT Immo																																								
SAMAND	Engine	OMVL																																								
SAMAND	Engine	Bosch MP7.3 (Sarir)																																								
SAMAND	Engine	Bifuel SIEMENS (XU7)																																								
SAMAND	Engine	Bosch ME 7.4.4 (TU5)																																								
SAMAND	Engine	Petrol SIEMENS (EF7)																																								
SAMAND	Engine	Bifuel SIEMENS (EF7)																																								
SAMAND	Engine	SIEMENS Micro Hybrid																																								
SAMAND	Engine	EF7 TC																																								
SAMAND	Engine	Bosch SSAT (XU7)																																								
SAMAND	Engine	Bifuel BOSCH ME7.4.9.NG (Euro4)																																								
SAMAND	Engine	Petrol BOSCH ME7.4.9.PT (Euro4)																																								
SAMAND	ABS	MANDO MGH25 / MGH60																																								
SAMAND	ABS	TEVES MK20																																								
SAMAND	ABS	TEVES MK70																																								
SAMAND	ABS	BOSCH																																								
SAMAND	ABS	Mobis																																								
SAMAND	AirBag	HAE 2.5																																								
SAMAND	AirBag	SRS																																								
SAMAND	AirBag	EIMEN																																								
SAMAND	AirBag	Crouse																																								
SAMAND	AirBag	Jin Heng																																								
SAMAND	Multiplex	CCN																																								
SAMAND	Multiplex	FN																																								
SAMAND	Multiplex	DDN																																								
SAMAND	Multiplex	PDN																																								
SAMAND	Multiplex	ICN																																								
SAMAND	EcoMux	BCM																																								
SAMAND	EcoMux	FCM																																								
SAMAND	EcoMux	ICN(Crouse)																																								
Peugeot 405	Engine	SL96																																								
Peugeot 405	Engine	S2000																																								
Peugeot 405	Engine	S2000 (LC)																																								
Peugeot 405	Engine	OMVL																																								
Peugeot 405	Engine	SAX500																																								
Peugeot 405	Engine	CNG BOSCH M7.4.4																																								
Peugeot 405	Engine	Petrol SIEMENS (XU7)																																								
Peugeot 405	Engine	Bifuel SIEMENS (XU7)																																								
Peugeot 405	Engine	Petrol SIEMENS (XUM)																																								
Peugeot 405	Engine	Bifuel BOSCH ME7.4.9NG																																								
Peugeot 405	Engine	Bifuel BOSCH ME7.4.9NG Immo																																								

Vehicle	System 1	System 2	Airbag Lock	Airbag Unlock	A/C Configuration	BSI Downloading ver 30	BSI Downloading ver 32	BSI Downloading ver 34	BSI Downloading ver 38	BSI Downloading Ver.40	BSI Downloading Ver.42	BSI Downloading Ver.44	BSI Downloading Ver.45	Replacement	Downloading	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room
Peugeot 405	Engine	Petrol BOSCH ME7.4.9PT Immo																																								
Peugeot 405	Engine	Bosch SSAT (XU7)																																								
Peugeot 405	ABS	MANDO MGH25 / MGH60																																								
Peugeot 405	ABS	TEVES MK20																																								
Peugeot 405	ABS	TEVES MK70																																								
Peugeot 405	ABS	BOSCH																																								
Peugeot 405	ABS	Mobis																																								
Peugeot 405	AirBag	HAE 2.5																																								
Peugeot 405	AirBag	SRS																																								
Peugeot 405	AirBag	EIMEN																																								
Peugeot 405	AirBag	Crouse																																								
Peugeot 405	AirBag	Jin Heng																																								
Peugeot Pars	Engine	SL96																																								
Peugeot Pars	Engine	S2000																																								
Peugeot Pars	Engine	S2000 (LC)																																								
Peugeot Pars	Engine	BOSCH M7.4.4																																								
Peugeot Pars	Engine	OMVL																																								
Peugeot Pars	Engine	Bosch MP7.3																																								
Peugeot Pars	Engine	Petrol SIEMENS (XU7)																																								
Peugeot Pars	Engine	Gas SIEMENS (CNG)																																								
Peugeot Pars	Engine	Bifuel SIEMENS (XU7)																																								
Peugeot Pars	Engine	Bifuel BOSCH ME7.4.9NG																																								
Peugeot Pars	Engine	Bifuel BOSCH ME7.4.9NG Immo																																								
Peugeot Pars	Engine	Petrol BOSCH ME7.4.9PT Immo																																								
Peugeot Pars	Engine	Petrol Siemens (XUM)																																								
Peugeot Pars	Engine	Bosch SSAT (XU7)																																								
Peugeot Pars	ABS	MANDO MGH25 / MGH60																																								
Peugeot Pars	ABS	TEVES MK20																																								
Peugeot Pars	ABS	TEVES MK70																																								
Peugeot Pars	ABS	BOSCH																																								
Peugeot Pars	ABS	Mobis																																								
Peugeot Pars	AirBag	HAE 2.5																																								
Peugeot Pars	AirBag	SRS																																								
Peugeot Pars	AirBag	EIMEN																																								
Peugeot Pars	AirBag	Crouse																																								
Peugeot Pars	AirBag	Jin Heng																																								
Vanet	Engine	SL96																																								
Vanet	Engine	S2000 (11)																																								
Vanet	Engine	S2000 (11)																																								
Vanet	Engine	Petrol SIEMENS (XU7)																																								
Vanet	Engine	Bifuel Siemens (XU7)																																								

Vehicle	System 1	System 2	Airbag Lock	Airbag Unlock	A/C Configuration	BSI Downloading ver 30	BSI Downloading ver 32	BSI Downloading ver 34	BSI Downloading ver 38	BSI Downloading Ver.40	BSI Downloading Ver.42	BSI Downloading Ver.44	BSI Downloading Ver.45	Replacement	Downloading	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room
Vanet	Engine	Gas Siemens (CNG)																																								
Vanet	ABS	MANDO MGH25 / MGH60																																								
Vanet	ABS	TEVES MK20																																								
Vanet	ABS	TEVES MK70																																								
Vanet	ABS	BOSCH																																								
Vanet	ABS	Mobis																																								
RUNNA	Engine	SIEMENS TU5																																								
RUNNA	ABS	MANDO MGH25 / MGH60																																								
RUNNA	ABS	TEVES MK20																																								
RUNNA	ABS	TEVES MK70																																								
RUNNA	ABS	BOSCH																																								
RUNNA	ABS	Mobis																																								
RUNNA	AirBag	HAE 2.5																																								
RUNNA	AirBag	SRS																																								
RUNNA	AirBag	EIMEN																																								
RUNNA	AirBag	Crouse																																								
RUNNA	AirBag	Jin Heng																																								
RUNNA	Multiplex	CCN																																								
RUNNA	Multiplex	FN																																								
RUNNA	Multiplex	MCN																																								
RUNNA	Multiplex	ICN																																								
RUNNA	EcoMux	BCM																																								
RUNNA	EcoMux	FCM																																								
RUNNA	EcoMux	ICN(Crouse)																																								
Peugeot 206 Localize	Engine	SIEMENS TU5 (CBM)																																								
Peugeot 206 Localize	ABS	MANDO MGH25 / MGH60																																								
Peugeot 206 Localize	ABS	TEVES MK20																																								
Peugeot 206 Localize	ABS	TEVES MK70																																								
Peugeot 206 Localize	ABS	BOSCH																																								
Peugeot 206 Localize	ABS	Mobis																																								
Peugeot 206 Localize	AirBag	HAE 2.5																																								
Peugeot 206 Localize	AirBag	SRS																																								
Peugeot 206 Localize	AirBag	EIMEN																																								
Peugeot 206 Localize	AirBag	Crouse																																								
Peugeot 206 Localize	AirBag	Jin Heng																																								
Peugeot 206 Localize	Multiplex	CCN																																								
Peugeot 206 Localize	Multiplex	FN																																								
Peugeot 206 Localize	Multiplex	ICN																																								
Peugeot 206 Localize	EcoMux	BCM																																								
Peugeot 206 Localize	EcoMux	FCM																																								
Peugeot 206 Localize	EcoMux	ICN(Crouse)																																								

Vehicle	System 1	System 2	Airbag Lock	Airbag Unlock	A/C Configuration	BSI Downloading ver 30	BSI Downloading ver 32	BSI Downloading ver 34	BSI Downloading ver 38	BSI Downloading Ver.40	BSI Downloading Ver.42	BSI Downloading Ver.44	BSI Downloading Ver.45	Replacement	Downloading	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room
Dena	Engine	SL96																																								
Dena	Engine	S2000																																								
Dena	Engine	S2000 (LC)																																								
Dena	Engine	Petrol SIEMENS (XU7)																																								
Dena	Engine	Bosch ME7.4.4																																								
Dena	Engine	Gas SIEMENS (CNG)																																								
Dena	Engine	Bifuel BOSCH ME7.4.9NG																																								
Dena	Engine	Bifuel BOSCH ME7.4.9NG Immo																																								
Dena	Engine	Petrol BOSCH ME7.4.9PT Immo																																								
Dena	Engine	OMVL																																								
Dena	Engine	Bosch MP7.3 (Sarir)																																								
Dena	Engine	Bifuel SIEMENS (XU7)																																								
Dena	Engine	Bosch ME 7.4.4 (TU5)																																								
Dena	Engine	Petrol SIEMENS EF7																																								
Dena	Engine	Bifuel SIEMENS EF7																																								
Dena	Engine	SIEMENS Micro Hybrid																																								
Dena	Engine	EF7 TC																																								
Dena	Engine	Bosch SSAT (XU7)																																								
Dena	Engine	Bifuel BOSCH ME7.4.9.NG (Euro4)																																								
Dena	Engine	Petrol BOSCH ME7.4.9.PT (Euro4)																																								
Dena	ABS	MANDO MGH25 / MGH60																																								
Dena	ABS	TEVES MK20																																								
Dena	ABS	TEVES MK70																																								
Dena	ABS	BOSCH																																								
Dena	ABS	Mobis																																								
Dena	AirBag	HAE 2.5																																								
Dena	AirBag	SRS																																								
Dena	AirBag	EIMEN																																								
Dena	AirBag	Crouse																																								
Dena	AirBag	Jin Heng																																								
Special Function	Key Learning	SIEMENS																																								
Special Function	Key Learning	VALEO																																								
Special Function	Key Learning	Peugeot 206																																								
Special Function	Key Learning	SIEMENS CIM																																								
Special Function	Key Learning	SSAT																																								
Special Function	ECU Reset	ECU Reset																																								

Connector	System	DTC	Freeze frame	CURRENT DATA	ACTUATION TEST	ECU INFORMATION	VIN Registration	EVAP system close	ECT Learning Value Clear	A/F Ratio Learning Value Clear	TARGET IGN TIN ADJ	TARGET IDLE RPM ADJ	Target Ignition Timing Adjustment	Idle Air Volume Learning(Quick TAS)	Fuel Pressure Release	Target Idle RPM Adjustment	TP Swich/TP Sensor Idle Position Adjust	Check Fuel Lines	V/T Control Learn	Ethanol M/R Adjust	EXH V/T Control Learn	TP Position Learn Clear	A/F Sensor Learn Clear	Service Generation	DIF EX PRE Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Enter Injector Calibration Data	PTO Registration	DPF Data Clear	OFF Accelerator Position Signal	Idle Air Volume Learning	Closed Throttle Position Learning	G Sensor Calibration	A/F INITIAL LEARNING	STRT OPRTN CNTR CLEAR	CML B/DCHRG CRNT CLEAR	Self-Learning Control	VVEL Position Sensor Adjustment Prep	Cumulative Sub-Battery Dischg Current Clear	Sub-Starter and Generator OPER Count Clear	SC Magnetic Clutch Engage Count Clear	Valve Timing Offset Data Clear	Wastegate Actuator Position Learn Value Clear	Enter Injector Calibration Data	EGR/V Learn Clear	PUMP LEANT CLEAR	DF EXH PRES SEN LEARN CLR	E/R AIR TEMP SEN LEARN CLR	FUEL INJ QUANTITY LEARNING
16PIN CONNECTOR	SYSTEM SEARCH																																																
16PIN CONNECTOR	Engine	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
16PIN CONNECTOR	AT/CVT	V		V	V	V																												V															
16PIN CONNECTOR	ABS(Antilock Braking System)	V		V	V	V	V																																										
16PIN CONNECTOR	Airbag	V		V		V																																							V	V			
16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)	V		V	V	V																																											
16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3	V		V		V																																											
16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)	V				V																																											
16PIN CONNECTOR	BCM(Body Control Module)	V		V	V	V																												V															
16PIN CONNECTOR	IPDM Engine Room	V		V	V	V																															V												
16PIN CONNECTOR	Intelligent Key	V		V	V	V																																											
16PIN CONNECTOR	Auto Drive Position	V		V	V	V																																											
16PIN CONNECTOR	Meter	V		V		V																																											
16PIN CONNECTOR	Meter/Air Conditioner Amplifier	V		V																																													
16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)	V		V		V																																											
16PIN CONNECTOR	Head Lamp Levelizer	V		V	V																																												
16PIN CONNECTOR	Auto Slide Door	V		V	V	V																																											
16PIN CONNECTOR	Auto Slide Door Right	V		V	V	V																																											
16PIN CONNECTOR	Precrash Seatbelt	V				V																																											
16PIN CONNECTOR	RAS/HICAS	V				V																																											
16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front	V				V																																											
16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)	V		V	V	V																																											
16PIN CONNECTOR	ICC(Intelligent Cruise Control)	V		V		V																																											
16PIN CONNECTOR	Pop Up Hood	V		V		V																																											
16PIN CONNECTOR	Air Pressure Monitor	V		V	V	V																																											
16PIN CONNECTOR	Multi AV	V		V		V																																											
16PIN CONNECTOR	E-Sus	V		V	V	V																																											
16PIN CONNECTOR	Auto Back Door	V		V		V																																											
16PIN CONNECTOR	Rear View Camera			V		V																																											
16PIN CONNECTOR	S/Blind Camera			V		V																																											
16PIN CONNECTOR	Lane Camera	V		V	V	V																																											
16PIN CONNECTOR	Air Levelizer	V		V	V	V																																											
16PIN CONNECTOR	Diff Lock	V		V		V																																											
16PIN CONNECTOR	Sonar	V		V	V	V																																											
16PIN CONNECTOR	Motor Assist	V		V																																													
16PIN CONNECTOR	CAN Gateway	V		V		V																																											
16PIN CONNECTOR	Chassis Control	V		V		V																																											
16PIN CONNECTOR	Laser/Radar	V		V		V																																											
16PIN CONNECTOR	Multi Display	V		V	V	V																																											
16PIN CONNECTOR	EHS/PKB	V		V	V	V																												V															
16PIN CONNECTOR	AVM(Around View Monitor)	V		V	V	V																																											

Connector	System	DTC	Freeze frame	CURRENT DATA	ACTUATION TEST	ECU INFORMATION	VIN Registration	EVAP system close	ECT Learning Value Clear	A/F Ratio Learning Value Clear	TARGET IGN TIN ADJ	TARGET IDLE RPM ADJ	Target Ignition Timing Adjustment	Idle Air Volume Learning(Quick TAS)	Fuel Pressure Release	Target Idle RPM Adjustment	TP Swich/TP Sensor Idle Position Adjust	Check Fuel Lines	V/T Control Learn	Ethanol M/R Adjust	EXH V/T Control Learn	TP Position Learn Clear	A/F Sensor Learn Clear	Service Generation	DIF EX PRE Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Enter Injector Calibration Data	PTO Registration	DPF Data Clear	OFF Accelerator Position Signal	Idle Air Volume Learning	Closed Throttle Position Learning	G Sensor Calibration	A/F INITIAL LEARNING	STRT OPRTN CNTR CLEAR	CML B/DCHRG CRNT CLEAR	Self-Learning Control	VVEL Position Sensor Adjustment Prep	Cumulative Sub-Battery Dischg Current Clear	Sub-Starter and Generator OPER Count Clear	SC Magnetic Clutch Engage Count Clear	Valve Timing Offset Data Clear	Wastegate Actuator Position Learn Value Clear	Enter Injector Calibration Data	EGR/V Learn Clear	PUMP LEANT CLEAR	DF EXH PRES SEN LEARN CLR	E/R AIR TEMP SEN LEARN CLR	FUEL INJ QUANTITY LEARNING
16PIN CONNECTOR	PTC Heater	V		V		V																																											
16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)	V		V	V	V																																											
16PIN CONNECTOR	ANC(Active Noise Control)	V		V	V	V																																											
16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)	V		V		V																																											
16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)	V		V		V																																											
16PIN CONNECTOR	Side Radar Left	V		V	V	V																																											
16PIN CONNECTOR	Side Radar Right	V		V	V	V																																											
16PIN CONNECTOR	EMCM	V		V		V																																											
16PIN CONNECTOR	BSW/Buzzer	V		V	V	V																																											
16PIN CONNECTOR	Accle Pedal ACT	V		V	V	V																																											
16PIN CONNECTOR	FSCM	V		V		V																																											
14PIN CONNECTOR	SYSTEM SEARCH																																																
14PIN CONNECTOR	Engine	V		V	V	V																																											
14PIN CONNECTOR	AT	V		V		V																																											
14PIN CONNECTOR	CVT	V		V		V																																											
14PIN CONNECTOR	ABS(Antilocked Braking System)	V		V		V																																											
14PIN CONNECTOR	Airbag	V				V																																											
14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)	V				V																																											

Connector	System	CONFIG CLR	INJ ADJ VAL CLR	EGR/V LEARN CLR	EXH PRSR SEN LEARN CLEAR	OC DATA CLEAR	PROGRAMMED VALUES	EGR ADAPTIVES	RESET PUMP FORCEFEEDING	RESET INJCTR ADAPTATIVE	TP POS LEARN CLR	EXH FUEL INJ DATA CLEAR	ZFC VALUE RESET	PRGRM REINITIALIZE	PRES REG ADAPTIVE	LEARNING	P062F EXCLUSIVE FUNCTION	ZFC VALVE RESET	OC DATA LEAR	ENTER INJECTOR CODES	After DPF Regeneration	After DPF Replacement	EGR Valve Programming	Air Damper Valve Programming	CC/SL Programming	E/O CC/SL Programming	FLYWHL TGT Programming	PRPR Rich Sensor Programming	Exhaust Throttle Valve Programming	Swirl Flap Programming	Turbocharger Programming	Adaptives on ETC Actuator Malfunction	Air Flow Meter Programming	Manifold Pressure Sensor Programming	DIFF Exhaust Press. Sensor	Low Pressure EGR Valve Programming	Engine Adaptives	Swirl Flap	Rail Press Sensor Adaptives	Number Of Starting Cycles	Injection Pump Adaptatives	Fuel Sply Prec	H/P Fuel Pump Initial Starts Counter Reset	H/P Fuel Pump Total Starts Counter Reset	INJ ADJ VAL Regist	Speed Limiter	Commercial VHCL Idle Speed MOD	Service Regeneration	Fuel Supply Prevention	Number of Starting 1
16PIN CONNECTOR	SYSTEM SEARCH																																																		
16PIN CONNECTOR	Engine	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
16PIN CONNECTOR	AT/CVT																																																		
16PIN CONNECTOR	ABS(Antilock Braking System)																																																		
16PIN CONNECTOR	Airbag																																																		
16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																																		
16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																																		
16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																																		
16PIN CONNECTOR	BCM(Body Control Module)																																																		
16PIN CONNECTOR	IPDM Engine Room																																																		
16PIN CONNECTOR	Intelligent Key																																																		
16PIN CONNECTOR	Auto Drive Position																																																		
16PIN CONNECTOR	Meter																																																		
16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																																		
16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																																		
16PIN CONNECTOR	Head Lamp Levelizer																																																		
16PIN CONNECTOR	Auto Slide Door																																																		
16PIN CONNECTOR	Auto Slide Door Right																																																		
16PIN CONNECTOR	Precrash Seatbelt																																																		
16PIN CONNECTOR	RAS/HICAS																																																		
16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																																		
16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																																		
16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																																		
16PIN CONNECTOR	Pop Up Hood																																																		
16PIN CONNECTOR	Air Pressure Monitor																																																		
16PIN CONNECTOR	Multi AV																																																		
16PIN CONNECTOR	E-Sus																																																		
16PIN CONNECTOR	Auto Back Door																																																		
16PIN CONNECTOR	Rear View Camera																																																		
16PIN CONNECTOR	S/Blind Camera																																																		
16PIN CONNECTOR	Lane Camera																																																		
16PIN CONNECTOR	Air Levelizer																																																		
16PIN CONNECTOR	Diff Lock																																																		
16PIN CONNECTOR	Sonar																																																		
16PIN CONNECTOR	Motor Assist																																																		
16PIN CONNECTOR	CAN Gateway																																																		
16PIN CONNECTOR	Chassis Control																																																		
16PIN CONNECTOR	Laser/Radar																																																		
16PIN CONNECTOR	Multi Display																																																		
16PIN CONNECTOR	EHS/PKB																																																		
16PIN CONNECTOR	AVM(Around View Monitor)																																																		

Connector	System	CONFIG CLR	INJ ADJ VAL CLR	EGR/V LEARN CLR	EXH PRSR SEN LEARN CLEAR	OC DATA CLEAR	PROGRAMMED VALUES	EGR ADAPTIVES	RESET PUMP FORCEFEEDING	RESET INJCTR ADAPTATIVE	TP POS LEARN CLR	EXH FUEL INJ DATA CLEAR	ZFC VALUE RESET	PRGRM REINITIALIZE	PRES REG ADAPTIVE	LEARNING	P062F EXCLUSIVE FUNCTION	ZFC VALVE RESET	OC DATA LEAR	ENTER INJECTOR CODES	After DPF Regeneration	After DPF Replacement	EGR Valve Programming	Air Damper Valve Programming	CC/SL Programming	E/O CC/SL Programming	FLYWHL TGT Programming	PRPR Rich Sensor Programming	Exhaust Throttle Valve Programming	Swirl Flap Programming	Turbocharger Programming	Adaptives on ETC Actuator Malfunction	Air Flow Meter Programming	Manifold Pressure Sensor Programming	DIFF Exhaust Press. Sensor	Low Pressure EGR Valve Programming	Engine Adaptives	Swirl Flap	Rail Press Sensor Adaptives	Number Of Starting Cycles	Injection Pump Adaptatives	Fuel Sply Prec	H/P Fuel Pump Initial Starts Counter Reset	H/P Fuel Pump Total Starts Counter Reset	INJ ADJ VAL Regist	Speed Limiter	Commercial VHCL Idle Speed MOD	Service Regeneration	Fuel Supply Prevention	Number of Starting 1
16PIN CONNECTOR	PTC Heater																																																		
16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																																		
16PIN CONNECTOR	ANC(Active Noise Control)																																																		
16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																																		
16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																																		
16PIN CONNECTOR	Side Radar Left																																																		
16PIN CONNECTOR	Side Radar Right																																																		
16PIN CONNECTOR	EMCM																																																		
16PIN CONNECTOR	BSW/Buzzer																																																		
16PIN CONNECTOR	Accle Pedal ACT																																																		
16PIN CONNECTOR	FSCM																																																		
14PIN CONNECTOR	SYSTEM SEARCH																																																		
14PIN CONNECTOR	Engine																																																		
14PIN CONNECTOR	AT																																																		
14PIN CONNECTOR	CVT																																																		
14PIN CONNECTOR	ABS(Antilocked Braking System)																																																		
14PIN CONNECTOR	Airbag																																																		
14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																																		

Connector	System	Number of Starting 2	Number of Starting 3	Number of Starting 4	Flywheel Target Programming	Exhaust Air Flap Programming	Adaptives on Air Intake Flap Malfunction	Fuel Pump Programming	Injector Adaptives	Air Path Programming	EGR Programming	Proportional Richness Sensor Programming	Fuel Rail Press Limiting Injection Counter Clear	Adaptives After Regenerating Particle Filter	A/F Sensor 1 Learn Clear	A/F Sensor 2 Learn Clear	TC Boost Control Actuator Position Learning	Read VIN	Decrement Idle Speed	Increment Idle Speed	Program Reinitialize	Lock Injector Control	Pressure Regulation Adaptives	Programmed Valves	EEPROM Clear Confirm	ENGINE BRAKE ADJ	CONFORM CVTF DETERIORATION	ECO MODE RESET FUNCTION	Initialization	G Sensor Calibration	Erase Calibration Data	Erase Learning Value	Erase Memory Data	Clutch Point Learning	Electric O.P. Air Bleeding	FWD Clutch Point Learning	MAX. Clutch STRK MSRMNT	Clutch Touchpoint Adjustment	TM Actuator Self Adjustment	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	Steering Angle Sensor Adjustment	Deceleration G Sensor Calibration	Valve Calibration	Stroke Sensor Calibration	Check Target Teeth	Bleed HYD Unit Brake Circle	Acceleation Sensor
16PIN CONNECTOR	SYSTEM SEARCH																																																	
16PIN CONNECTOR	Engine	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																										
16PIN CONNECTOR	AT/CVT																								V	V	V	V	V	V	V	V	V	V	V	V	V	V												
16PIN CONNECTOR	ABS(Antilock Braking System)																																						V	V	V	V	V	V	V	V	V	V	V
16PIN CONNECTOR	Airbag																																																	
16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																																	
16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																																	
16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																																	
16PIN CONNECTOR	BCM(Body Control Module)																																						V											
16PIN CONNECTOR	IPDM Engine Room																																																	
16PIN CONNECTOR	Intelligent Key																																																	
16PIN CONNECTOR	Auto Drive Position																																																	
16PIN CONNECTOR	Meter																																																	
16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																																	
16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																						V											
16PIN CONNECTOR	Head Lamp Levelizer																																																	
16PIN CONNECTOR	Auto Slide Door																																																	
16PIN CONNECTOR	Auto Slide Door Right																																																	
16PIN CONNECTOR	Precrash Seatbelt																																																	
16PIN CONNECTOR	RAS/HICAS																																																	
16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																																	
16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																																	
16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																																	
16PIN CONNECTOR	Pop Up Hood																																																	
16PIN CONNECTOR	Air Pressure Monitor																																																	
16PIN CONNECTOR	Multi AV																																											V						
16PIN CONNECTOR	E-Sus																																																	
16PIN CONNECTOR	Auto Back Door																																																	
16PIN CONNECTOR	Rear View Camera																																																	
16PIN CONNECTOR	S/Blind Camera																																																	
16PIN CONNECTOR	Lane Camera																																																	
16PIN CONNECTOR	Air Levelizer																																																	
16PIN CONNECTOR	Diff Lock																																																	
16PIN CONNECTOR	Sonar																																																	
16PIN CONNECTOR	Motor Assist																																																	
16PIN CONNECTOR	CAN Gateway																																																	
16PIN CONNECTOR	Chassis Control																																																	
16PIN CONNECTOR	Laser/Radar																																																	
16PIN CONNECTOR	Multi Display																																																	
16PIN CONNECTOR	EHS/PKB																																																	
16PIN CONNECTOR	AVM(Around View Monitor)																																																	

Connector	System	Number of Starting 2	Number of Starting 3	Number of Starting 4	Flywheel Target Programming	Exhaust Air Flap Programming	Adaptives on Air Intake Flap Malfunction	Fuel Pump Programming	Injector Adaptives	Air Path Programming	EGR Programming	Proportional Richness Sensor Programming	Fuel Rail Press Limiting Injection Counter Clear	Adaptives After Regenerating Particle Filter	A/F Sensor 1 Learn Clear	A/F Sensor 2 Learn Clear	TC Boost Control Actuator Position Learning	Read VIN	Decrement Idle Speed	Increment Idle Speed	Program Reinitialize	Lock Injector Control	Pressure Regulation Adaptives	Programmed Valves	EEPROM Clear Confirm	ENGINE BRAKE ADJ	CONFORM CVTF DETERIORATION	ECO MODE RESET FUNCTION	Initialization	G Sensor Calibration	Erase Calibration Data	Erase Learning Value	Erase Memory Data	Clutch Point Learning	Electric O.P. Air Bleeding	FWD Clutch Point Learning	MAX. Clutch STRK MSRMNT	Clutch Touchpoint Adjustment	TM Actuator Self Adjustment	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	Steering Angle Sensor Adjustment	Deceleration G Sensor Calibration	Valve Calibration	Stroke Sensor Calibration	Check Target Teeth	Bleed HYD Unit Brake Circle	Acceleation Sensor
16PIN CONNECTOR	PTC Heater																																																	
16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																																	
16PIN CONNECTOR	ANC(Active Noise Control)																																																	
16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																																	
16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																																	
16PIN CONNECTOR	Side Radar Left																																																	
16PIN CONNECTOR	Side Radar Right																																																	
16PIN CONNECTOR	EMCM																																																	
16PIN CONNECTOR	BSW/Buzzer																																																	
16PIN CONNECTOR	Accle Pedal ACT																																																	
16PIN CONNECTOR	FSCM																																																	
14PIN CONNECTOR	SYSTEM SEARCH																																																	
14PIN CONNECTOR	Engine																																																	
14PIN CONNECTOR	AT																																																	
14PIN CONNECTOR	CVT																																																	
14PIN CONNECTOR	ABS(Antilocked Braking System)																																																	
14PIN CONNECTOR	Airbag																																																	
14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																																	

Connector	System	Steering Wheel Angle Sensor	Write Date Of Last After Sales OPE	Speedo Index	Config Clear	Injector Adpatation Valve Clear	Pump Learn Clear	Lock Computer	Unlock Computer	Steering Angle Adjustment	Power Steering Fluid Air Bleeding	C/U Initialization (20 digts)	Program Mode	C/U Initialization	RESET SETTING VALUE	Steering Lock Release (Key ID Erase)	DOOR LOCK-UNLOCK SET	AUTOMATIC DOOR LOCK SELECT	AUTOMATIC DOOR UNLOCK SELECT	AUTOMATIC DOOR LOCK/UNLOCK SELECT	Signature Light Setting	R Lamp Timer Logic Set	Room Lamp On Time Set	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	Fog Lamp Override	AUTO LIGHT LOGIC SET	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	ILL DELAY SET	HEAD LIGHT TIMER	Drop Wiper Function Set	Rain Sensor Wiper Function Set	WIPER SPEED SETTING	HAZARD ANSWER BACK	Remote Climate Cont Answer Back Function	ROOM LAMP BAT SAV SET	ROOM LAMP TIMER SET	IGN Battery Saver Set	ACC Battery Saver Set	PW DOWN SET	LOCK/UNLOCK BY I-KEY	TRUNK/GLASS HATCH OPEN	Anti Key Lock In Function	Answer Back I-Key Unlock	Intelligent Key Link Set	Answer Back I-Key Lock	HORN WITH KEYLESS LOCK	ENGINE START BY I-KEY
16PIN CONNECTOR	SYSTEM SEARCH																																																
16PIN CONNECTOR	Engine																																																
16PIN CONNECTOR	AT/CVT																																																
16PIN CONNECTOR	ABS(Antilock Braking System)	V	V	V																																													
16PIN CONNECTOR	Airbag				V	V	V	V	V																																								
16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																																
16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3									V	V																																						
16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)											V	V	V																																			
16PIN CONNECTOR	BCM(Body Control Module)														V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
16PIN CONNECTOR	IPDM Engine Room																																																
16PIN CONNECTOR	Intelligent Key																																			V							V	V					V	V
16PIN CONNECTOR	Auto Drive Position																																																
16PIN CONNECTOR	Meter																																																
16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																																
16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																																
16PIN CONNECTOR	Head Lamp Levelizer																																																
16PIN CONNECTOR	Auto Slide Door																																																
16PIN CONNECTOR	Auto Slide Door Right																																																
16PIN CONNECTOR	Precrash Seatbelt																																																
16PIN CONNECTOR	RAS/HICAS																																																
16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																																
16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																																
16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																																
16PIN CONNECTOR	Pop Up Hood																																																
16PIN CONNECTOR	Air Pressure Monitor																																																
16PIN CONNECTOR	Multi AV																																																
16PIN CONNECTOR	E-Sus																																																
16PIN CONNECTOR	Auto Back Door																																																
16PIN CONNECTOR	Rear View Camera																																																
16PIN CONNECTOR	S/Blind Camera																																																
16PIN CONNECTOR	Lane Camera																																																
16PIN CONNECTOR	Air Levelizer																																																
16PIN CONNECTOR	Diff Lock																																																
16PIN CONNECTOR	Sonar																																																
16PIN CONNECTOR	Motor Assist																																																
16PIN CONNECTOR	CAN Gateway																																																
16PIN CONNECTOR	Chassis Control																																																
16PIN CONNECTOR	Laser/Radar																																																
16PIN CONNECTOR	Multi Display																																																
16PIN CONNECTOR	EHS/PKB																																																
16PIN CONNECTOR	AVM(Around View Monitor)																																																

Connector	System	Steering Wheel Angle Sensor	Write Date Of Last After Sales OPE	Speedo Index	Config Clear	Injector Adpatation Valve Clear	Pump Learn Clear	Lock Computer	Unlock Computer	Steering Angle Adjustment	Power Steering Fluid Air Bleeding	C/U Initialization (20 digts)	Program Mode	C/U Initialization	RESET SETTING VALUE	Steering Lock Release (Key ID Erase)	DOOR LOCK-UNLOCK SET	AUTOMATIC DOOR LOCK SELECT	AUTOMATIC DOOR UNLOCK SELECT	AUTOMATIC DOOR LOCK/UNLOCK SELECT	Signature Light Setting	R Lamp Timer Logic Set	Room Lamp On Time Set	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	Fog Lamp Override	AUTO LIGHT LOGIC SET	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	ILL DELAY SET	HEAD LIGHT TIMER	Drop Wiper Function Set	Rain Sensor Wiper Function Set	WIPER SPEED SETTING	HAZARD ANSWER BACK	Remote Climate Cont Answer Back Function	ROOM LAMP BAT SAV SET	ROOM LAMP TIMER SET	IGN Battery Saver Set	ACC Battery Saver Set	PW DOWN SET	LOCK/UNLOCK BY I-KEY	TRUNK/GLASS HATCH OPEN	Anti Key Lock In Function	Answer Back I-Key Unlock	Intelligent Key Link Set	Answer Back I-Key Lock	HORN WITH KEYLESS LOCK	ENGINE START BY I-KEY
16PIN CONNECTOR	PTC Heater																																																		
16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																																		
16PIN CONNECTOR	ANC(Active Noise Control)																																																		
16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																																		
16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																																		
16PIN CONNECTOR	Side Radar Left																																																		
16PIN CONNECTOR	Side Radar Right																																																		
16PIN CONNECTOR	EMCM																																																		
16PIN CONNECTOR	BSW/Buzzer																																																		
16PIN CONNECTOR	Accle Pedal ACT																																																		
16PIN CONNECTOR	FSCM																																																		
14PIN CONNECTOR	SYSTEM SEARCH																																																		
14PIN CONNECTOR	Engine																																																		
14PIN CONNECTOR	AT																																																		
14PIN CONNECTOR	CVT																																																		
14PIN CONNECTOR	ABS(Antilocked Braking System)																																																		
14PIN CONNECTOR	Airbag																																																		
14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																																		

Connector	System	INSIDE ANT DIAGNOSIS	WELCOME LIGHT OP SET	CONFIRM KEY FOB ID	Retractable Mirror Set	SHORT CRANKING OUTPUT	WELCOME LIGHT SELECT	PANIC ALARM SET	LO-BATT OF KEY FOB WARN	AUTO LOCK SET	ANSWER BACK FUNCTION	TRUNK OPEN DELAY	THEFT ALM TRG	SECURITY ALARM SET(SIREN)	SECURITY ALARM SET	SIREN SET	CONFIRM DONGLE ID	ID READ	ID REGIST	Switching The Status of TPMS Beteen On and Off	Switch TPMS Between On/Off	SECURITY DOOR LOCK SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK	RR WIP RVRS SET	HAZARD LAMP SET	D/LOCK VHCL SPD AJT	HORN CHIRP SET	DROP WIPE FUNC SET	RAIN SEN WIP FUNC SET	TAKE OUT FROM WINDDOW WARN	KEYLESS FUNCTION	TRUNK OPEN SET	ANTI-LOCK OUT SET	REMO CONT ID ERASUR	REMO CONT ID REGIST	REMO CONT ID CONFIR	MULTI ANSWER BACK SET	RETAINED PWR SET	ANTI KEY LOCK IN FUNCTI	SECURITY ALARM SET	THEFT ALM TRG	HZRD REM SET	CUSTOM A/LIGHT SETTING	Auto ACC Function (Audio/Navi Set After IGN Off)	Auto Unlock Type	Auto Lock Function	Auto Unlock Function
16PIN CONNECTOR	SYSTEM SEARCH																																																	
16PIN CONNECTOR	Engine																																																	
16PIN CONNECTOR	AT/CVT																																																	
16PIN CONNECTOR	ABS(Antilock Braking System)																																																	
16PIN CONNECTOR	Airbag																																																	
16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																																	
16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																																	
16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																																	
16PIN CONNECTOR	BCM(Body Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
16PIN CONNECTOR	IPDM Engine Room																																																	
16PIN CONNECTOR	Intelligent Key							V			V																					V	V	V	V															
16PIN CONNECTOR	Auto Drive Position																																																	
16PIN CONNECTOR	Meter																																																	
16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																																	
16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																																	
16PIN CONNECTOR	Head Lamp Levelizer																																																	
16PIN CONNECTOR	Auto Slide Door																																																	
16PIN CONNECTOR	Auto Slide Door Right																																																	
16PIN CONNECTOR	Precrash Seatbelt																																																	
16PIN CONNECTOR	RAS/HICAS																																																	
16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																																	
16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																																	
16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																																	
16PIN CONNECTOR	Pop Up Hood																																																	
16PIN CONNECTOR	Air Pressure Monitor																		V	V																														
16PIN CONNECTOR	Multi AV																																																	
16PIN CONNECTOR	E-Sus																																																	
16PIN CONNECTOR	Auto Back Door																																																	
16PIN CONNECTOR	Rear View Camera																																																	
16PIN CONNECTOR	S/Blind Camera																																																	
16PIN CONNECTOR	Lane Camera																																																	
16PIN CONNECTOR	Air Levelizer																																																	
16PIN CONNECTOR	Diff Lock																																																	
16PIN CONNECTOR	Sonar																																																	
16PIN CONNECTOR	Motor Assist																																																	
16PIN CONNECTOR	CAN Gateway																																																	
16PIN CONNECTOR	Chassis Control																																																	
16PIN CONNECTOR	Laser/Radar																																																	
16PIN CONNECTOR	Multi Display																																																	
16PIN CONNECTOR	EHS/PKB																																																	
16PIN CONNECTOR	AVM(Around View Monitor)																																																	

Connector	System	INSIDE ANT DIAGNOSIS	WELCOME LIGHT OP SET	CONFIRM KEY FOB ID	Retractable Mirror Set	SHORT CRANKING OUTPUT	WELCOME LIGHT SELECT	PANIC ALARM SET	LO-BATT OF KEY FOB WARN	AUTO LOCK SET	ANSWER BACK FUNCTION	TRUNK OPEN DELAY	THEFT ALM TRG	SECURITY ALARM SET(SIREN)	SECURITY ALARM SET	SIREN SET	CONFIRM DONGLE ID	ID READ	ID REGIST	Switching The Status of TPMS Beteen On and Off	Switch TPMS Between On/Off	SECURITY DOOR LOCK SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK	RR WIP RVRS SET	HAZARD LAMP SET	D/LOCK VHCL SPD AJT	HORN CHIRP SET	DROP WIPE FUNC SET	RAIN SEN WIP FUNC SET	TAKE OUT FROM WINDDOW WARN	KEYLESS FUNCTION	TRUNK OPEN SET	ANTI-LOCK OUT SET	REMO CONT ID ERASUR	REMO CONT ID REGIST	REMO CONT ID CONFIR	MULTI ANSWER BACK SET	RETAINED PWR SET	ANTI KEY LOCK IN FUNCTI	SECURITY ALARM SET	THEFT ALM TRG	HZRD REM SET	CUSTOM A/LIGHT SETTING	Auto ACC Function (Audio/Navi Set After IGN Off)	Auto Unlock Type	Auto Lock Function	Auto Unlock Function
16PIN CONNECTOR	PTC Heater																																																	
16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																																	
16PIN CONNECTOR	ANC(Active Noise Control)																																																	
16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																																	
16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																																	
16PIN CONNECTOR	Side Radar Left																																																	
16PIN CONNECTOR	Side Radar Right																																																	
16PIN CONNECTOR	EMCM																																																	
16PIN CONNECTOR	BSW/Buzzer																																																	
16PIN CONNECTOR	Accle Pedal ACT																																																	
16PIN CONNECTOR	FSCM																																																	
14PIN CONNECTOR	SYSTEM SEARCH																																																	
14PIN CONNECTOR	Engine																																																	
14PIN CONNECTOR	AT																																																	
14PIN CONNECTOR	CVT																																																	
14PIN CONNECTOR	ABS(Antilocked Braking System)																																																	
14PIN CONNECTOR	Airbag																																																	
14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																																	

Connector	System	Set R-DEF Timer	Answerback Keyless Lock Unlock	Twilight ON	Wiper Link	Daytime Running Light Setting	Rain Sensor	FR RR Drip	Rear Wiper Link With Reverse Setting	3-Time Flasher Setting	IGN/ACC Battery Saver	Answer Back I-Key Lock Unlock	Answerback I-Key Lock Unlock	LEVELIZER ADJUSTMEN	ANSWER BACK WITH I-KEY UNLOCK	CONFIRM KEY FOR ID	LOW BATT OF KEY FOR WARN	I-KEY FUNCTION	SELECTIVE UNLOCK FUNCTION	ANSWER BACK WITH I-KEY LOCK	AUTO RELOCK TIMER	P/W DOWN DELAY	LUG ROOM ENGINE START	Intelligent Key Register	EXIT SEAT SLIDE SETTING	EXIT TILT SETTING	SEAT SLIDE VOLUME SET	Outside Air Temperature Diagnosis	Fuel meter diagnosis(analog pointer)	Warning lamp diagnosis	SENSOR INITIALISE	TEMP Set Correct	REC Memory Set	FRE Memory Set	Blow Set	Gas Sensor Adjustment	Clean SW Set	Door Motor Starting Position Reset	Target Evaporator Temp Upper Limit Setting	Stop/Start System Operation Cond Setting	Air Inlet Change Setting	Air Flow Reduction Setting	Aroma Setting	Fragrance Setting	Blower Motor Setting	Aroma Diffuser Setting	Rear Temp Set Correct	Target Max RPM Adjust At Pre-Climate	Target Max RPM Adjust At Idle	*COMP Operation At DEF(PRI_A/C)(TBD)
16PIN CONNECTOR	SYSTEM SEARCH																																																
16PIN CONNECTOR	Engine																																																
16PIN CONNECTOR	AT/CVT																																																
16PIN CONNECTOR	ABS(Antilock Braking System)																																																
16PIN CONNECTOR	Airbag																																																
16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																																
16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																																
16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																																
16PIN CONNECTOR	BCM(Body Control Module)	V	V	V	V	V	V	V	V	V	V	V	V																																				
16PIN CONNECTOR	IPDM Engine Room																																																
16PIN CONNECTOR	Intelligent Key															V	V	V	V	V	V	V	V	V																									
16PIN CONNECTOR	Auto Drive Position																								V	V	V																							
16PIN CONNECTOR	Meter																											V	V	V																				
16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																																
16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																																
16PIN CONNECTOR	Head Lamp Levelizer																														V																		
16PIN CONNECTOR	Auto Slide Door																																																
16PIN CONNECTOR	Auto Slide Door Right																																																
16PIN CONNECTOR	Precrash Seatbelt																																																
16PIN CONNECTOR	RAS/HICAS																																																
16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																																
16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																															V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																																
16PIN CONNECTOR	Pop Up Hood																																																
16PIN CONNECTOR	Air Pressure Monitor																																																
16PIN CONNECTOR	Multi AV																																																
16PIN CONNECTOR	E-Sus																																																
16PIN CONNECTOR	Auto Back Door																																																
16PIN CONNECTOR	Rear View Camera																																																
16PIN CONNECTOR	S/Blind Camera																																																
16PIN CONNECTOR	Lane Camera																																																
16PIN CONNECTOR	Air Levelizer																																																
16PIN CONNECTOR	Diff Lock																																																
16PIN CONNECTOR	Sonar																																																
16PIN CONNECTOR	Motor Assist																																																
16PIN CONNECTOR	CAN Gateway																																																
16PIN CONNECTOR	Chassis Control																																																
16PIN CONNECTOR	Laser/Radar																																																
16PIN CONNECTOR	Multi Display																																																
16PIN CONNECTOR	EHS/PKB																																																
16PIN CONNECTOR	AVM(Around View Monitor)																																																

Connector	System	Set R-DEF Timer	Answerback Keyless Lock Unlock	Twilight ON	Wiper Link	Daytime Running Light Setting	Rain Sensor	FR RR Drip	Rear Wiper Link With Reverse Setting	3-Time Flasher Setting	IGN/ACC Battery Saver	Answer Back I-Key Lock Unlock	Answerback I-Key Lock Unlock	LEVELIZER ADJUSTMEN	ANSWER BACK WITH I-KEY UNLOCK	CONFIRM KEY FOR ID	LOW BATT OF KEY FOR WARN	I-KEY FUNCTION	SELECTIVE UNLOCK FUNCTION	ANSWER BACK WITH I-KEY LOCK	AUTO RELOCK TIMER	P/W DOWN DELAY	LUG ROOM ENGINE START	Intelligent Key Register	EXIT SEAT SLIDE SETTING	EXIT TILT SETTING	SEAT SLIDE VOLUME SET	Outside Air Temperature Diagnosis	Fuel meter diagnosis(analog pointer)	Warning lamp diagnosis	SENSOR INITIALISE	TEMP Set Correct	REC Memory Set	FRE Memory Set	Blow Set	Gas Sensor Adjustment	Clean SW Set	Door Motor Starting Position Reset	Target Evaporator Temp Upper Limit Setting	Stop/Start System Operation Cond Setting	Air Inlet Change Setting	Air Flow Reduction Setting	Aroma Setting	Fragrance Setting	Blower Motor Setting	Aroma Diffuser Setting	Rear Temp Set Correct	Target Max RPM Adjust At Pre-Climate	Target Max RPM Adjust At Idle	*COMP Operation At DEF(PRI_A/C)(TBD)
16PIN CONNECTOR	PTC Heater																																																
16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																																
16PIN CONNECTOR	ANC(Active Noise Control)																																																
16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																																
16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																																
16PIN CONNECTOR	Side Radar Left																																																
16PIN CONNECTOR	Side Radar Right																																																
16PIN CONNECTOR	EMCM																																																
16PIN CONNECTOR	BSW/Buzzer																																																
16PIN CONNECTOR	Accle Pedal ACT																																																
16PIN CONNECTOR	FSCM																																																
14PIN CONNECTOR	SYSTEM SEARCH																																																
14PIN CONNECTOR	Engine																																																
14PIN CONNECTOR	AT																																																
14PIN CONNECTOR	CVT																																																
14PIN CONNECTOR	ABS(Antilocked Braking System)																																																
14PIN CONNECTOR	Airbag																																																
14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																																

Connector	System	FEB default setting	Steering Angle Sensor Adjustment	FRONT RIGHT ACTUATOR	FRONT LEFT ACTUATOR	REAR RIGHT ACTUATOR	REAR LEFT ACTUATOR	FOUR WHEEL ACTUATOR	Auto AIM	AIM Check	STANDARD HEIGHT LEVEL	ADJUST HEIGHT INI	CLEAR HEIGHT INI	Corner Sensor Distance Set	Center Sensor Distance Set	Volume Setting	Trailer Hitch Mode	CALIBRATE ALL	Trailer Hitch Detection Range Adjustment	FEB Default Setting	Cause of Auto-Cancel	Actuator 0 Point Learning	Start Brake Pad Replacement	Finish Brake Pad Replacement	Initialization Position Dajustment	Clutch Sensor Reset	Brake Operation	Brake Relese	System Mode Change	Auto Activation On (AT/CVT)	Non-Viewable Area Reminder	Select Language of Warning Message	Predictive Course Line Display	Initalize Camera Image Calibration	Steering Angle Sensor Adjustment	Parts With Door Mirror Auto Fold Function	Sonar Off Pop-Up Display Setting Change	Cause Of LDW Cancel	Cause Of BSW Cancel	Cause OF IPA Cancel	Cause Of PSR Cancel	Calibrating Camera Image (Front Camera)	Calibrating Camera Image (Pass-Side Camera)	Calibrating Camera Image (DR-Side Camera)	Calibrating Camera Image (Rear Camera)	ANC SETTING	ASC SETTING	CK Fuel Press and INTRNL LKTGHTNSS of FL System	Actuation of Fuel Pump
16PIN CONNECTOR	SYSTEM SEARCH																																																
16PIN CONNECTOR	Engine																																																
16PIN CONNECTOR	AT/CVT																																																
16PIN CONNECTOR	ABS(Antilock Braking System)																																																
16PIN CONNECTOR	Airbag																																																
16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																																
16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																																
16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																																
16PIN CONNECTOR	BCM(Body Control Module)																																																
16PIN CONNECTOR	IPDM Engine Room																																																
16PIN CONNECTOR	Intelligent Key																																																
16PIN CONNECTOR	Auto Drive Position																																																
16PIN CONNECTOR	Meter																																																
16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																																
16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																																
16PIN CONNECTOR	Head Lamp Levelizer																																																
16PIN CONNECTOR	Auto Slide Door																																																
16PIN CONNECTOR	Auto Slide Door Right																																																
16PIN CONNECTOR	Precrash Seatbelt																																																
16PIN CONNECTOR	RAS/HICAS																																																
16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																																
16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																																
16PIN CONNECTOR	ICC(Intelligent Cruise Control)	V																																															
16PIN CONNECTOR	Pop Up Hood																																																
16PIN CONNECTOR	Air Pressure Monitor																																																
16PIN CONNECTOR	Multi AV		V																																														
16PIN CONNECTOR	E-Sus			V	V	V	V	V																																										
16PIN CONNECTOR	Auto Back Door																																																
16PIN CONNECTOR	Rear View Camera																																																
16PIN CONNECTOR	S/Blind Camera																																																
16PIN CONNECTOR	Lane Camera								V	V																																							
16PIN CONNECTOR	Air Levelizer										V	V	V																																				
16PIN CONNECTOR	Diff Lock																																																
16PIN CONNECTOR	Sonar													V	V	V	V		V																														
16PIN CONNECTOR	Motor Assist																	V																															
16PIN CONNECTOR	CAN Gateway																																																
16PIN CONNECTOR	Chassis Control																																																
16PIN CONNECTOR	Laser/Radar																			V	V																												
16PIN CONNECTOR	Multi Display																																																
16PIN CONNECTOR	EHS/PKB																					V	V	V	V	V	V	V	V	V																			
16PIN CONNECTOR	AVM(Around View Monitor)																														V	V	V	V	V	V	V	V	V	V	V	V	V	V					

Connector	System	FEB default setting	Steering Angle Sensor Adjustment	FRONT RIGHT ACTUATOR	FRONT LEFT ACTUATOR	REAR RIGHT ACTUATOR	REAR LEFT ACTUATOR	FOUR WHEEL ACTUATOR	Auto AIM	AIM Check	STANDARD HEIGHT LEVEL	ADJUST HEIGHT INI	CLEAR HEIGHT INI	Corner Sensor Distance Set	Center Sensor Distance Set	Volume Setting	Trailer Hitch Mode	CALIBRATE ALL	Trailer Hitch Detection Range Adjustment	FEB Default Setting	Cause of Auto-Cancel	Actuator 0 Point Learning	Start Brake Pad Replacement	Finish Brake Pad Replacement	Initialization Position Dajustment	Clutch Sensor Reset	Brake Operation	Brake Relese	System Mode Change	Auto Activation On (AT/CVT)	Non-Viewable Area Reminder	Select Language of Warning Message	Predictive Course Line Display	Initalize Camera Image Calibration	Steering Angle Sensor Adjustment	Parts With Door Mirror Auto Fold Function	Sonar Off Pop-Up Display Setting Change	Cause Of LDW Cancel	Cause Of BSW Cancel	Cause OF IPA Cancel	Cause Of PSR Cancel	Calibrating Camera Image (Front Camera)	Calibrating Camera Image (Pass-Side Camera)	Calibrating Camera Image (DR-Side Camera)	Calibrating Camera Image (Rear Camera)	ANC SETTING	ASC SETTING	CK Fuel Press and INTRNL LKTGHTNSS of FL System	Actuation of Fuel Pump
16PIN CONNECTOR	PTC Heater																																																	
16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																																	
16PIN CONNECTOR	ANC(Active Noise Control)																																													V	V			
16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																																	
16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																																	
16PIN CONNECTOR	Side Radar Left																																																	
16PIN CONNECTOR	Side Radar Right																																																	
16PIN CONNECTOR	EMCM																																																	
16PIN CONNECTOR	BSW/Buzzer																																																	
16PIN CONNECTOR	Accle Pedal ACT																																																	
16PIN CONNECTOR	FSCM																																															V	V
14PIN CONNECTOR	SYSTEM SEARCH																																																	
14PIN CONNECTOR	Engine																																																	
14PIN CONNECTOR	AT																																																	
14PIN CONNECTOR	CVT																																																	
14PIN CONNECTOR	ABS(Antilocked Braking System)																																																	
14PIN CONNECTOR	Airbag																																																	
14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																																	

Area	Group	Model	Type	System 1	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Initialization steering central position	Forced learning steering central position	SCR Catalyst data reset	NOx Sensor 1 data reset	Exhaust gas temperature sensor 3 data reset	Urea DCM(Dosing control module) data reset	Oxidation catalyst data reset	Urea fluid injector data reset	Clear learning value	Clear steering centered position	Idle learn	Fuel trim learn	Fuel trim reset	HO2S Heater learn	Register steering centered position	DPF Automatic regeneration	DPD Automatic regeneration reset	Reset O2 loop block learn map	Program vehicle type	Program speedometer gear	Program engine type	Program transmission type	Program speed meter type	Program final gear ratio	Program tire size(BETA)	Program tire compensation	Program ABS install
International	PICKUP TRUCK/SUV	New D-MAX	Diesel Engine	4JK1-TC(2.5)	V	V	V	V	V																V	V										
International	PICKUP TRUCK/SUV	New D-MAX	Diesel Engine	4JJ1-TC(3.0)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	New D-MAX	Gasoline Engine	Z32SED	V	V	V	V	V											V	V	V	V													
International	PICKUP TRUCK/SUV	New D-MAX	Transmission	AT	V	V	V	V	V									V																		
International	PICKUP TRUCK/SUV	New D-MAX	Chassis	ABS	V	V	V	V	V										V					V												
International	PICKUP TRUCK/SUV	New D-MAX	Chassis	Transfer case module	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	New D-MAX	Body	Immobilizer(BETA)	V	V	V		V																											
International	PICKUP TRUCK/SUV	New D-MAX	Body	PESS(Passive entry and start system)	V	V		V	V																											
International	PICKUP TRUCK/SUV	New D-MAX	Body	BCM	V	V			V																											
International	PICKUP TRUCK/SUV	New D-MAX	Body	Meter					V																											
International	PICKUP TRUCK/SUV	New D-MAX	Body	SRS Airbag	V	V			V																											
International	PICKUP TRUCK/SUV	MU-7	Diesel Engine	4JJ1-TC	V	V	V																													
International	PICKUP TRUCK/SUV	MU-7	Transmission	AT	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	MU-7	Chassis	ABS	V	V																														
International	PICKUP TRUCK/SUV	MU-7	Body	Immobilizer	V	V	V		V																											
International	PICKUP TRUCK/SUV	MU-7	Body	BCM	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	MU-7	Body	SRS Airbag	V	V	V		V																											
International	PICKUP TRUCK/SUV	MU-X	Diesel Engine	4JJ1-TC	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	MU-X	Transmission	AT	V	V	V	V	V									V																		
International	PICKUP TRUCK/SUV	MU-X	Chassis	ABS	V	V	V	V	V										V					V												
International	PICKUP TRUCK/SUV	MU-X	Chassis	Transfer case module	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	MU-X	Body	Immobilizer(BETA)	V	V	V		V																											
International	PICKUP TRUCK/SUV	MU-X	Body	PESS(Passive entry and start system)	V	V		V	V																											
International	PICKUP TRUCK/SUV	MU-X	Body	BCM	V	V			V																											
International	PICKUP TRUCK/SUV	MU-X	Body	Meter					V																											
International	PICKUP TRUCK/SUV	MU-X	Body	SRS Airbag	V	V			V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	6VD1	V	V	V	V																												
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.2 L4 SOHC	V	V	V		V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.X L4 HV240	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.4 LP1 EURO3	V	V	V	V	V																	V										
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	3.2 V6 6VD1 hitachi	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	3.5 V6 6VE1 hitachi	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	V6 Engine	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	2.8L Diesel(LWH)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JX1(3.0 L4)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JH1(2.5)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JH1-TC(3.0 iTD)	V	V	V	V	V																											

Area	Group	Model	Type	System 1	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Initialization steering central position	Forced learning steering central position	SCR Catalyst data reset	NOx Sensor 1 data reset	Exhaust gas temperature sensor 3 data reset	Urea DCM(Dosing control module) data reset	Oxidation catalyst data reset	Urea fluid injector data reset	Clear learning value	Clear steering centered position	Idle learn	Fuel trim learn	Fuel trim reset	HO2S Heater learn	Register steering centered position	DPF Automatic regeneration	DPD Automatic regeneration reset	Reset O2 loop block learn map	Program vehicle type	Program speedometer gear	Program engine type	Program transmission type	Program speed meter type	Program final gear ratio	Program tire size(BETA)	Program tire compensation	Program ABS install
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1-TC(Delphi)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1-TC(Transtron)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1(2.5 Delphi)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1(2.5 Transtron)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1(3.0 Delphi)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1(3.0 Transtron)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Transmission	AT	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Transmission	AT(6SP)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	ABS/ASR	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	EBCM(Electronic brake control module)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Transfer case module	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Multi-Axis acceleration sensor module	V	V			V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Steering wheel angle sensor module	V	V			V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(Old type)	V	V	V		V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(New type)	V	V	V		V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(New D-MAX))																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	PIM(Powertrain interface module)	V	V			V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	SRS Airbag	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	BCM	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	BCM(MIMAMORI)	V	V	V		V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	IPC(Instrument cluster)	V	V	V	V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Aniti theft warning	V	V		V	V																											
International	N Series(Light duty)	Engine	4HF1		V	V	V		V																											
International	N Series(Light duty)	Engine	4HE1-TC		V	V	V		V																											
International	N Series(Light duty)	Engine	4HJ1		V	V	V	V	V																											
International	N Series(Light duty)	Engine	4HG1		V	V	V		V																											
International	N Series(Light duty)	Engine	4JG2		V	V	V	V																												
International	N Series(Light duty)	Engine	4HL1		V	V	V	V	V																											
International	N Series(Light duty)	Engine	4HL1(Vehicle interface module)				V		V																											
International	N Series(Light duty)	Engine	4HL1-NA	'04.06~'05.04	V	V	V	V	V																											
International	N Series(Light duty)	Engine	4HL1-NA	'05.05~'06.10	V	V	V	V	V																											
International	N Series(Light duty)	Engine	4HL1-TC		V	V	V	V	V																											
International	N Series(Light duty)	Engine	4HK1(North America)		V	V	V	V	V																											
International	N Series(Light duty)	Engine	4HK1-TC	EURO2/3	V	V	V	V	V																											
International	N Series(Light duty)	Engine	4HK1-TC	EURO4	V	V	V	V	V																V											
International	N Series(Light duty)	Engine	4HK1-TC	EURO5	V	V	V	V	V																											
International	N Series(Light duty)	Engine	4HK1-TC	EURO6	V	V	V	V	V																V											

Area	Group	Model	Type	System 1	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Initialization steering central position	Forced learning steering central position	SCR Catalyst data reset	NOx Sensor 1 data reset	Exhaust gas temperature sensor 3 data reset	Urea DCM(Dosing control module) data reset	Oxidation catalyst data reset	Urea fluid injector data reset	Clear learning value	Clear steering centered position	Idle learn	Fuel trim learn	Fuel trim reset	HO2S Heater learn	Register steering centered position	DPF Automatic regeneration	DPD Automatic regeneration reset	Reset O2 loop block learn map	Program vehicle type	Program speedometer gear	Program engine type	Program transmission type	Program speed meter type	Program final gear ratio	Program tire size(BETA)	Program tire compensation	Program ABS install
International	N Series(Light duty)	Engine	UreaSCR EURO6		V	V	V	V	V			V	V	V	V	V	V																			
International	N Series(Light duty)	Engine	4JJ1-TC	EURO2/3	V	V	V	V	V																											
International	N Series(Light duty)	Engine	4JJ1-TC	EURO4	V	V	V	V	V																V											
International	N Series(Light duty)	Engine	4JJ1-TC	EURO5	V	V	V	V	V																V											
International	N Series(Light duty)	Engine	4JJ1-TC (PNLT)		V	V	V		V																											
International	N Series(Light duty)	Engine	4HV1(CNG)		V	V	V		V																											
International	N Series(Light duty)	Engine	4HF1(CNG)		V	V	V		V																											
International	N Series(Light duty)	Engine	4JG2(LPG)		V	V	V		V																											
International	N Series(Light duty)	Engine	4HG1(LPG)		V	V	V		V																											
International	N Series(Light duty)	Transmission	AT		V	V	V		V																											
International	N Series(Light duty)	Transmission	AT(North America)		V	V	V	V																												
International	N Series(Light duty)	Transmission	SMOOTHER	SMOOTHER-EX	V	V	V		V																		V	V	V	V	V	V	V	V	V
International	N Series(Light duty)	Transmission	SMOOTHER	SMOOTHER-E/AS	V	V	V		V																		V	V	V	V	V	V	V	V	V
International	N Series(Light duty)	Chassis	ABS(North America)		V	V	V	V																												
International	N Series(Light duty)	Chassis	ABS/ASR		V	V	V	V	V																											
International	N Series(Light duty)	Chassis	ABS EURO6		V	V	V		V	V	V																									
International	N Series(Light duty)	Chassis	HSA/CFS		V	V			V																											
International	N Series(Light duty)	Body	BCM		V	V	V		V																											
International	N Series(Light duty)	Body	BCM(MIMAMORI)		V	V	V		V																											
International	N Series(Light duty)	Body	SRS Airbag		V	V	V		V																											
International	N Series(Light duty)	Body	Immobilizer		V	V	V		V																											
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	GEN(3Pin)	V	V	V	V	V																											
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	EURO2/3	V	V	V	V	V																											
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	EURO4	V	V	V	V	V																V											
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	EURO5	V	V	V	V	V																											
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	GEN(3Pin)	V	V	V	V	V																											
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	GEN(20Pin)	V	V	V		V																											
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	EURO2/3	V	V	V	V	V																											
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	EURO4	V	V	V	V	V																											
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	EURO5	V	V	V	V	V																V											
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	GEN(3Pin)	V	V	V	V	V																											
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	GEN(20Pin)	V	V			V																											
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	EURO 2/3	V	V	V	V	V																											
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	EURO 4	V	V	V	V	V																V											
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	EURO 5	V	V	V	V	V																											
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC	EURO2/3	V	V	V	V	V																											
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC	EURO4	V	V	V	V	V																V											

Area	Group	Model	Type	System 1	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Initialization steering central position	Forced learning steering central position	SCR Catalyst data reset	NOx Sensor 1 data reset	Exhaust gas temperature sensor 3 data reset	Urea DCM(Dosing control module) data reset	Oxidation catalyst data reset	Urea fluid injector data reset	Clear learning value	Clear steering centered position	Idle learn	Fuel trim learn	Fuel trim reset	HO2S Heater learn	Register steering centered position	DPF Automatic regeneration	DPD Automatic regeneration reset	Reset O2 loop block learn map	Program vehicle type	Program speedometer gear	Program engine type	Program transmission type	Program speed meter type	Program final gear ratio	Program tire size(BETA)	Program tire compensation	Program ABS install
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC	EURO5	V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC (PNLT)		V	V	V		V																												
International	F/G Series(Medium/Heavy duty)	Engine	6SD1		V	V	V		V																												
International	F/G Series(Medium/Heavy duty)	Engine	6UZ1		V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	6WF1		V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-Red4		V	V	V		V																												
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-C/Rail		V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	6UZ1-TC		V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC	EURO2/3	V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC	EURO4	V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC	EURO5	V	V	V	V	V															V													
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC (PNLT)		V	V	V		V																												
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-TC	EURO2/3	V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-TC	EURO4	V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	10TD1			V	V		V																												
International	F/G Series(Medium/Heavy duty)	Transmission	AT		V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Transmission	SMOOTHER		V	V	V	V	V																					V	V		V	V		V
International	F/G Series(Medium/Heavy duty)	Chassis	ABS/ASR ADVICS		V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Chassis	ABS/ASR		V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Chassis	ABS/IESC		V	V	V		V																												
International	F/G Series(Medium/Heavy duty)	Chassis	Air Suspension		V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Body	BCM		V	V	V		V																												
International	F/G Series(Medium/Heavy duty)	Body	BCM(MIMAMORI)		V	V	V		V																												
International	F/G Series(Medium/Heavy duty)	Body	SRS Airbag		V	V	V		V																												
International	F/G Series(Medium/Heavy duty)	Body	Immobilizer		V	V	V		V																												
International	LV/LT Series(Bus)	Engine	4HK1	GEN(3Pin)	V	V	V	V	V																												
International	LV/LT Series(Bus)	Engine	4HK1	EURO2/3	V	V	V	V	V																												
International	LV/LT Series(Bus)	Engine	4HK1	EURO4	V	V	V	V	V															V													
International	LV/LT Series(Bus)	Engine	4HK1	EURO5	V	V	V	V	V																												
International	LV/LT Series(Bus)	Engine	6HK1	GEN(3Pin)	V	V	V	V	V																												
International	LV/LT Series(Bus)	Engine	6HK1	GEN(20Pin)	V	V	V		V																												
International	LV/LT Series(Bus)	Engine	6HK1	EURO2/3	V	V	V	V	V																												
International	LV/LT Series(Bus)	Engine	6HK1	EURO4	V	V	V	V	V																												
International	LV/LT Series(Bus)	Engine	6HK1	EURO5	V	V	V	V	V															V													
International	LV/LT Series(Bus)	Engine	6HL1	GEN(3Pin)	V	V	V	V	V																												
International	LV/LT Series(Bus)	Engine	6HL1	GEN(20Pin)	V	V			V																												
International	LV/LT Series(Bus)	Engine	6HL1	EURO 2/3	V	V	V	V	V																												

Area	Group	Model	Type	System 1	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	Initialization steering central position	Forced learning steering central position	SCR Catalyst data reset	NOx Sensor 1 data reset	Exhaust gas temperature sensor 3 data reset	Urea DCM(Dosing control module) data reset	Oxidation catalyst data reset	Urea fluid injector data reset	Clear learning value	Clear steering centered position	Idle learn	Fuel trim learn	Fuel trim reset	HO2S Heater learn	Register steering centered position	DPF Automatic regeneration	DPD Automatic regeneration reset	Reset O2 loop block learn map	Program vehicle type	Program speedometer gear	Program engine type	Program transmission type	Program speed meter type	Program final gear ratio	Program tire size(BETA)	Program tire compensation	Program ABS install
International	LV/LT Series(Bus)	Engine	6HL1	EURO 4	V	V	V	V	V																V											
International	LV/LT Series(Bus)	Engine	6HL1	EURO 5	V	V	V	V	V																											
International	LV/LT Series(Bus)	Engine	4HK1-TC	EURO2/3	V	V	V	V	V																											
International	LV/LT Series(Bus)	Engine	4HK1-TC	EURO4	V	V	V	V	V																V											
International	LV/LT Series(Bus)	Engine	4HK1-TC	EURO5	V	V	V	V	V																											
International	LV/LT Series(Bus)	Engine	6UZ1		V	V	V	V	V																											
International	LV/LT Series(Bus)	Engine	6WF1		V	V	V	V	V																											
International	LV/LT Series(Bus)	Engine	6WG1		V	V	V	V	V																											
International	LV/LT Series(Bus)	Engine	6UZ1-TC		V	V	V	V	V																											
International	LV/LT Series(Bus)	Engine	6HK1-TC	EURO2/3	V	V	V	V	V																											
International	LV/LT Series(Bus)	Engine	6HK1-TC	EURO4	V	V	V	V	V																											
International	LV/LT Series(Bus)	Engine	6HK1-TC	EURO5	V	V	V	V	V																V											
International	LV/LT Series(Bus)	Engine	6WG1-TC	EURO2/3	V	V	V	V	V																											
International	LV/LT Series(Bus)	Engine	6WG1-TC	EURO4	V	V	V	V	V																											
International	LV/LT Series(Bus)	Transmission	AT		V	V	V	V	V																											
International	LV/LT Series(Bus)	Transmission	SMOOTHER		V	V	V		V																											
International	LV/LT Series(Bus)	Chassis	ABS/ASR		V	V		V	V																											
International	LV/LT Series(Bus)	Chassis	ABS/IESC		V	V	V		V																											
International	LV/LT Series(Bus)	Chassis	Air Suspension		V	V	V	V	V																											
International	LV/LT Series(Bus)	Body	BCM		V	V	V		V																											
International	LV/LT Series(Bus)	Body	BCM(MIMAMORI)		V	V	V		V																											
International	LV/LT Series(Bus)	Body	SRS Airbag		V	V	V		V																											
International	LV/LT Series(Bus)	Body	Immobilizer		V	V	V		V																											

Area	Group	Model	Type	System 1	Program elevating work platform	Program PTO request engine speed	Program tire compensation	VIN Programming	Injector quantity trim	Injector programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)	Program remote keys	Erase remote keys	Program immobilizer function	Reset ECM	IAC Reset	Reset O2 BLM	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Registeration	Injector ID code Read/Write (ECU change)	ID Code History	MAF Correction Data Check	MAF Correction Data Service Mode	MAF Correction Data Read/Write (ECU change)	Erasing the Learned Supply Pump	Q-Correction Data Check	Q-Correction Data Read/Write (ECU change)	Engine Start Counter(Replacing ECU)	Engine Start Counter(Replacing Starter)	DPD normal regeneration control	DPD slow regeneration control
International	PICKUP TRUCK/SUV	New D-MAX	Diesel Engine	4JK1-TC(2.5)																															V	V
International	PICKUP TRUCK/SUV	New D-MAX	Diesel Engine	4JJ1-TC(3.0)																																
International	PICKUP TRUCK/SUV	New D-MAX	Gasoline Engine	Z32SED																																
International	PICKUP TRUCK/SUV	New D-MAX	Transmission	AT																																
International	PICKUP TRUCK/SUV	New D-MAX	Chassis	ABS																																
International	PICKUP TRUCK/SUV	New D-MAX	Chassis	Transfer case module																																
International	PICKUP TRUCK/SUV	New D-MAX	Body	Immobilizer(BETA)																																
International	PICKUP TRUCK/SUV	New D-MAX	Body	PESS(Passive entry and start system)																																
International	PICKUP TRUCK/SUV	New D-MAX	Body	BCM																																
International	PICKUP TRUCK/SUV	New D-MAX	Body	Meter																																
International	PICKUP TRUCK/SUV	New D-MAX	Body	SRS Airbag																																
International	PICKUP TRUCK/SUV	MU-7	Diesel Engine	4JJ1-TC																																
International	PICKUP TRUCK/SUV	MU-7	Transmission	AT																																
International	PICKUP TRUCK/SUV	MU-7	Chassis	ABS																																
International	PICKUP TRUCK/SUV	MU-7	Body	Immobilizer																																
International	PICKUP TRUCK/SUV	MU-7	Body	BCM																																
International	PICKUP TRUCK/SUV	MU-7	Body	SRS Airbag																																
International	PICKUP TRUCK/SUV	MU-X	Diesel Engine	4JJ1-TC																																
International	PICKUP TRUCK/SUV	MU-X	Transmission	AT																																
International	PICKUP TRUCK/SUV	MU-X	Chassis	ABS																																
International	PICKUP TRUCK/SUV	MU-X	Chassis	Transfer case module																																
International	PICKUP TRUCK/SUV	MU-X	Body	Immobilizer(BETA)																																
International	PICKUP TRUCK/SUV	MU-X	Body	PESS(Passive entry and start system)																																
International	PICKUP TRUCK/SUV	MU-X	Body	BCM																																
International	PICKUP TRUCK/SUV	MU-X	Body	Meter																																
International	PICKUP TRUCK/SUV	MU-X	Body	SRS Airbag																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	6VD1															V																	
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.2 L4 SOHC																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.X L4 HV240												V	V	V																		
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.4 LP1 EURO3				V																												
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	3.2 V6 6VD1 hitachi																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	3.5 V6 6VE1 hitachi												V	V																			
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	V6 Engine													V																			
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	2.8L Diesel(LWH)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JX1(3.0 L4)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JH1(2.5)																V	V	V														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JH1-TC(3.0 iTD)												V	V																			

Area	Group	Model	Type	System 1	Program elevating work platform	Program PTO request engine speed	Program tire compensation	VIN Programming	Injector quantity trim	Injector programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)	Program remote keys	Erase remote keys	Program immobilizer function	Reset ECM	IAC Reset	Reset O2 BLM	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Registeration	Injector ID code Read/Write (ECU change)	ID Code History	MAF Correction Data Check	MAF Correction Data Service Mode	MAF Correction Data Read/Write (ECU change)	Erasing the Learned Supply Pump	Q-Correction Data Check	Q-Correction Data Read/Write (ECU change)	Engine Start Counter(Replacing ECU)	Engine Start Counter(Replacing Starter)	DPD normal regeneration control	DPD slow regeneration control
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1-TC(Delphi)																V	V	V														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1-TC(Transtron)																V	V	V														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1(2.5 Delphi)																V	V	V														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1(2.5 Transtron)																V	V	V														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1(3.0 Delphi)																V	V	V														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1(3.0 Transtron)																V	V	V														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Transmission	AT																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Transmission	AT(6SP)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	ABS/ASR																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	EBCM(Electronic brake control module)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Transfer case module																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Multi-Axis acceleration sensor module																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Steering wheel angle sensor module																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(Old type)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(New type)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(New D-MAX))																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	PIM(Powertrain interface module)							V	V	V																							
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	SRS Airbag																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	BCM																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	BCM(MIMAMORI)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	IPC(Instrument cluster)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Aniti theft warning										V	V																					
International	N Series(Light duty)	Engine	4HF1																																	
International	N Series(Light duty)	Engine	4HE1-TC																																	
International	N Series(Light duty)	Engine	4HJ1																																	
International	N Series(Light duty)	Engine	4HG1																																	
International	N Series(Light duty)	Engine	4JG2																																	
International	N Series(Light duty)	Engine	4HL1																											V						
International	N Series(Light duty)	Engine	4HL1(Vehicle interface module)																													V	V			
International	N Series(Light duty)	Engine	4HL1-NA	'04.06~'05.04																V		V	V	V	V			V	V				V	V		
International	N Series(Light duty)	Engine	4HL1-NA	'05.05~'06.10																V		V	V	V	V			V	V				V	V		
International	N Series(Light duty)	Engine	4HL1-TC																				V	V	V								V	V		
International	N Series(Light duty)	Engine	4HK1(North America)																																	
International	N Series(Light duty)	Engine	4HK1-TC	EURO2/3																V	V	V	V	V	V		V	V	V	V						
International	N Series(Light duty)	Engine	4HK1-TC	EURO4																															V	V
International	N Series(Light duty)	Engine	4HK1-TC	EURO5																															V	V
International	N Series(Light duty)	Engine	4HK1-TC	EURO6																															V	V

Area	Group	Model	Type	System 1	Program elevating work platform	Program PTO request engine speed	Program tire compensation	VIN Programming	Injector quantity trim	Injector programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)	Program remote keys	Erase remote keys	Program immobilizer function	Reset ECM	IAC Reset	Reset O2 BLM	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Registeration	Injector ID code Read/Write (ECU change)	ID Code History	MAF Correction Data Check	MAF Correction Data Service Mode	MAF Correction Data Read/Write (ECU change)	Erasing the Learned Supply Pump	Q-Correction Data Check	Q-Correction Data Read/Write (ECU change)	Engine Start Counter(Replacing ECU)	Engine Start Counter(Replacing Starter)	DPD normal regeneration control	DPD slow regeneration control
International	N Series(Light duty)	Engine	UreaSCR EURO6																																	
International	N Series(Light duty)	Engine	4JJ1-TC	EURO2/3																V	V	V	V	V	V		V	V	V	V						
International	N Series(Light duty)	Engine	4JJ1-TC	EURO4																															V	V
International	N Series(Light duty)	Engine	4JJ1-TC	EURO5																															V	V
International	N Series(Light duty)	Engine	4JJ1-TC (PNLT)																	V	V	V	V	V	V		V	V	V	V						
International	N Series(Light duty)	Engine	4HV1(CNG)																																	
International	N Series(Light duty)	Engine	4HF1(CNG)																																	
International	N Series(Light duty)	Engine	4JG2(LPG)																																	
International	N Series(Light duty)	Engine	4HG1(LPG)																																	
International	N Series(Light duty)	Transmission	AT																																	
International	N Series(Light duty)	Transmission	AT(North America)																																	
International	N Series(Light duty)	Transmission	SMOOTHER	SMOOTHER-EX	V	V	V	V																												
International	N Series(Light duty)	Transmission	SMOOTHER	SMOOTHER-E/AS	V	V	V	V																												
International	N Series(Light duty)	Chassis	ABS(North America)																																	
International	N Series(Light duty)	Chassis	ABS/ASR																																	
International	N Series(Light duty)	Chassis	ABS EURO6																																	
International	N Series(Light duty)	Chassis	HSA/CFS																																	
International	N Series(Light duty)	Body	BCM																																	
International	N Series(Light duty)	Body	BCM(MIMAMORI)																																	
International	N Series(Light duty)	Body	SRS Airbag																																	
International	N Series(Light duty)	Body	Immobilizer																																	
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	GEN(3Pin)																V	V	V	V	V	V		V	V	V				V	V		
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	EURO2/3																V	V	V	V	V	V		V	V	V	V						
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	EURO4																															V	V
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	EURO5																															V	V
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	GEN(3Pin)																			V	V	V						V	V	V	V		
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	GEN(20Pin)																											V	V				
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	EURO2/3																V	V	V	V	V	V		V	V	V	V						
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	EURO4																															V	V
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	EURO5																															V	V
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	GEN(3Pin)																V		V	V	V	V		V	V	V		V	V	V	V		
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	GEN(20Pin)																											V	V				
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	EURO 2/3																V	V	V	V	V	V		V	V	V	V						
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	EURO 4																															V	V
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	EURO 5																															V	V
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC	EURO2/3																V	V	V	V	V	V		V	V	V	V						
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC	EURO4																															V	V

Area	Group	Model	Type	System 1	Program elevating work platform	Program PTO request engine speed	Program tire compensation	VIN Programming	Injector quantity trim	Injector programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)	Program remote keys	Erase remote keys	Program immobilizer function	Reset ECM	IAC Reset	Reset O2 BLM	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Registeration	Injector ID code Read/Write (ECU change)	ID Code History	MAF Correction Data Check	MAF Correction Data Service Mode	MAF Correction Data Read/Write (ECU change)	Erasing the Learned Supply Pump	Q-Correction Data Check	Q-Correction Data Read/Write (ECU change)	Engine Start Counter(Replacing ECU)	Engine Start Counter(Replacing Starter)	DPD normal regeneration control	DPD slow regeneration control
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC	EURO5																															V	V
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC (PNLT)																	V	V	V	V	V	V		V	V	V	V						
International	F/G Series(Medium/Heavy duty)	Engine	6SD1																													V				
International	F/G Series(Medium/Heavy duty)	Engine	6UZ1					V	V	V										V	V	V	V	V	V						V	V	V	V		
International	F/G Series(Medium/Heavy duty)	Engine	6WF1																				V	V	V	V					V	V			V	V
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-Red4																												V					
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-C/Rail																				V	V	V	V					V	V			V	V
International	F/G Series(Medium/Heavy duty)	Engine	6UZ1-TC					V	V	V										V	V	V	V	V	V		V		V	V	V	V				
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC	EURO2/3																V	V	V	V	V	V		V	V	V	V	V	V				
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC	EURO4																															V	V
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC	EURO5																															V	V
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC (PNLT)																	V	V	V	V	V	V		V	V	V	V	V	V				
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-TC	EURO2/3																V	V	V	V	V	V		V		V	V	V	V				
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-TC	EURO4																															V	V
International	F/G Series(Medium/Heavy duty)	Engine	10TD1																													V				
International	F/G Series(Medium/Heavy duty)	Transmission	AT																																	
International	F/G Series(Medium/Heavy duty)	Transmission	SMOOTHER			V																														
International	F/G Series(Medium/Heavy duty)	Chassis	ABS/ASR ADVICS																																	
International	F/G Series(Medium/Heavy duty)	Chassis	ABS/ASR																																	
International	F/G Series(Medium/Heavy duty)	Chassis	ABS/IESC																																	
International	F/G Series(Medium/Heavy duty)	Chassis	Air Suspension																																	
International	F/G Series(Medium/Heavy duty)	Body	BCM																																	
International	F/G Series(Medium/Heavy duty)	Body	BCM(MIMAMORI)																																	
International	F/G Series(Medium/Heavy duty)	Body	SRS Airbag																																	
International	F/G Series(Medium/Heavy duty)	Body	Immobilizer																																	
International	LV/LT Series(Bus)	Engine	4HK1	GEN(3Pin)																V	V	V	V	V	V		V	V	V				V	V		
International	LV/LT Series(Bus)	Engine	4HK1	EURO2/3																V	V	V	V	V	V		V	V	V	V						
International	LV/LT Series(Bus)	Engine	4HK1	EURO4																															V	V
International	LV/LT Series(Bus)	Engine	4HK1	EURO5																															V	V
International	LV/LT Series(Bus)	Engine	6HK1	GEN(3Pin)																			V	V	V						V	V	V	V		
International	LV/LT Series(Bus)	Engine	6HK1	GEN(20Pin)																											V	V				
International	LV/LT Series(Bus)	Engine	6HK1	EURO2/3																V	V	V	V	V	V		V	V	V	V						
International	LV/LT Series(Bus)	Engine	6HK1	EURO4																															V	V
International	LV/LT Series(Bus)	Engine	6HK1	EURO5																															V	V
International	LV/LT Series(Bus)	Engine	6HL1	GEN(3Pin)																V		V	V	V	V		V	V	V		V	V	V	V		
International	LV/LT Series(Bus)	Engine	6HL1	GEN(20Pin)																											V	V				
International	LV/LT Series(Bus)	Engine	6HL1	EURO 2/3																V	V	V	V	V	V		V	V	V	V						

Area	Group	Model	Type	System 1	Program elevating work platform	Program PTO request engine speed	Program tire compensation	VIN Programming	Injector quantity trim	Injector programming	Reset PIM	Link to ECM/Immobilizer to PIM(V6 Engine)	Link to PIM to ECM/Immobilizer(V6 engine)	Program remote keys	Erase remote keys	Program immobilizer function	Reset ECM	IAC Reset	Reset O2 BLM	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Registeration	Injector ID code Read/Write (ECU change)	ID Code History	MAF Correction Data Check	MAF Correction Data Service Mode	MAF Correction Data Read/Write (ECU change)	Erasing the Learned Supply Pump	Q-Correction Data Check	Q-Correction Data Read/Write (ECU change)	Engine Start Counter(Replacing ECU)	Engine Start Counter(Replacing Starter)	DPD normal regeneration control	DPD slow regeneration control
International	LV/LT Series(Bus)	Engine	6HL1	EURO 4																															V	V
International	LV/LT Series(Bus)	Engine	6HL1	EURO 5																															V	V
International	LV/LT Series(Bus)	Engine	4HK1-TC	EURO2/3																V	V	V	V	V	V		V	V	V	V						
International	LV/LT Series(Bus)	Engine	4HK1-TC	EURO4																															V	V
International	LV/LT Series(Bus)	Engine	4HK1-TC	EURO5																															V	V
International	LV/LT Series(Bus)	Engine	6UZ1					V	V	V										V	V	V	V	V	V						V	V	V	V		
International	LV/LT Series(Bus)	Engine	6WF1																				V	V	V	V					V	V			V	V
International	LV/LT Series(Bus)	Engine	6WG1																				V	V	V	V					V	V			V	V
International	LV/LT Series(Bus)	Engine	6UZ1-TC					V	V	V										V	V	V	V	V	V		V		V	V	V	V				
International	LV/LT Series(Bus)	Engine	6HK1-TC	EURO2/3																V	V	V	V	V	V		V	V	V	V	V	V				
International	LV/LT Series(Bus)	Engine	6HK1-TC	EURO4																															V	V
International	LV/LT Series(Bus)	Engine	6HK1-TC	EURO5																															V	V
International	LV/LT Series(Bus)	Engine	6WG1-TC	EURO2/3																V	V	V	V	V	V		V		V	V	V	V				
International	LV/LT Series(Bus)	Engine	6WG1-TC	EURO4																															V	V
International	LV/LT Series(Bus)	Transmission	AT																																	
International	LV/LT Series(Bus)	Transmission	SMOOTHER																																	
International	LV/LT Series(Bus)	Chassis	ABS/ASR																																	
International	LV/LT Series(Bus)	Chassis	ABS/IESC																																	
International	LV/LT Series(Bus)	Chassis	Air Suspension																																	
International	LV/LT Series(Bus)	Body	BCM																																	
International	LV/LT Series(Bus)	Body	BCM(MIMAMORI)																																	
International	LV/LT Series(Bus)	Body	SRS Airbag																																	
International	LV/LT Series(Bus)	Body	Immobilizer																																	

Area	Group	Model	Type	System 1	DPD status resetting	Injector ID Code Read	Injector programming	Injector Quantity Trim	Supply Pump Initializtion	Clear adaptation to fast + base	Reset autodetection information	Engine oil distance resetting	Transmission oil distance resetting	Fuel consumption data resetting	Accumulated engine runtime resetting	ENG log data force recording	T/M log data force recording	Accumulated ENG log data clearing	Accumulated T/M log data clearing	Recording DTC data clearing	All accumulation data clearing	Engine oil exchange reset	Injector ID Code Verification	Injector ID Code Resistration	Fuel trim reset	Throttle body relearn	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	TAP CELLS RESET	Program transponder key	Erase transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)
International	PICKUP TRUCK/SUV	New D-MAX	Diesel Engine	4JK1-TC(2.5)	V	V	V		V																											
International	PICKUP TRUCK/SUV	New D-MAX	Diesel Engine	4JJ1-TC(3.0)		V	V		V																											
International	PICKUP TRUCK/SUV	New D-MAX	Gasoline Engine	Z32SED		V	V		V																											
International	PICKUP TRUCK/SUV	New D-MAX	Transmission	AT																																
International	PICKUP TRUCK/SUV	New D-MAX	Chassis	ABS																																
International	PICKUP TRUCK/SUV	New D-MAX	Chassis	Transfer case module																																
International	PICKUP TRUCK/SUV	New D-MAX	Body	Immobilizer(BETA)																											V	V				
International	PICKUP TRUCK/SUV	New D-MAX	Body	PESS(Passive entry and start system)																																
International	PICKUP TRUCK/SUV	New D-MAX	Body	BCM																																
International	PICKUP TRUCK/SUV	New D-MAX	Body	Meter																																
International	PICKUP TRUCK/SUV	New D-MAX	Body	SRS Airbag																																
International	PICKUP TRUCK/SUV	MU-7	Diesel Engine	4JJ1-TC		V	V		V																											
International	PICKUP TRUCK/SUV	MU-7	Transmission	AT																										V						
International	PICKUP TRUCK/SUV	MU-7	Chassis	ABS																																
International	PICKUP TRUCK/SUV	MU-7	Body	Immobilizer																											V	V				
International	PICKUP TRUCK/SUV	MU-7	Body	BCM																																
International	PICKUP TRUCK/SUV	MU-7	Body	SRS Airbag																																
International	PICKUP TRUCK/SUV	MU-X	Diesel Engine	4JJ1-TC		V	V		V																											
International	PICKUP TRUCK/SUV	MU-X	Transmission	AT																																
International	PICKUP TRUCK/SUV	MU-X	Chassis	ABS																																
International	PICKUP TRUCK/SUV	MU-X	Chassis	Transfer case module																																
International	PICKUP TRUCK/SUV	MU-X	Body	Immobilizer(BETA)																											V	V				
International	PICKUP TRUCK/SUV	MU-X	Body	PESS(Passive entry and start system)																																
International	PICKUP TRUCK/SUV	MU-X	Body	BCM																																
International	PICKUP TRUCK/SUV	MU-X	Body	Meter																																
International	PICKUP TRUCK/SUV	MU-X	Body	SRS Airbag																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	6VD1																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.2 L4 SOHC																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.X L4 HV240																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.4 LP1 EURO3																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	3.2 V6 6VD1 hitachi																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	3.5 V6 6VE1 hitachi																					V											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	V6 Engine																					V	V	V									
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	2.8L Diesel(LWH)																			V	V												
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JX1(3.0 L4)																								V	V							
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JH1(2.5)																			V													
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JH1-TC(3.0 iTD)																																

Area	Group	Model	Type	System 1	DPD status resetting	Injector ID Code Read	Injector programming	Injector Quantity Trim	Supply Pump Initializtion	Clear adaptation to fast + base	Reset autodetection information	Engine oil distance resetting	Transmission oil distance resetting	Fuel consumption data resetting	Accumulated engine runtime resetting	ENG log data force recording	T/M log data force recording	Accumulated ENG log data clearing	Accumulated T/M log data clearing	Recording DTC data clearing	All accumulation data clearing	Engine oil exchange reset	Injector ID Code Verification	Injector ID Code Resistration	Fuel trim reset	Throttle body relearn	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	TAP CELLS RESET	Program transponder key	Erase transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1-TC(Delphi)		V	V		V														V	V												
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1-TC(Transtron)		V	V		V														V	V												
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1(2.5 Delphi)		V	V		V														V	V												
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1(2.5 Transtron)		V	V		V														V	V												
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1(3.0 Delphi)		V	V		V														V	V												
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1(3.0 Transtron)		V	V		V														V	V												
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Transmission	AT																										V						
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Transmission	AT(6SP)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	ABS/ASR																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	EBCM(Electronic brake control module)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Transfer case module																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Multi-Axis acceleration sensor module																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Steering wheel angle sensor module																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(Old type)																											V	V				
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(New type)																											V	V				
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(New D-MAX))																											V					
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	PIM(Powertrain interface module)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	SRS Airbag																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	BCM																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	BCM(MIMAMORI)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	IPC(Instrument cluster)																																
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Aniti theft warning																																
International	N Series(Light duty)	Engine	4HF1																																	
International	N Series(Light duty)	Engine	4HE1-TC																																	
International	N Series(Light duty)	Engine	4HJ1																																	
International	N Series(Light duty)	Engine	4HG1																																	
International	N Series(Light duty)	Engine	4JG2																																	
International	N Series(Light duty)	Engine	4HL1																																	
International	N Series(Light duty)	Engine	4HL1(Vehicle interface module)																																	
International	N Series(Light duty)	Engine	4HL1-NA	'04.06~'05.04																																
International	N Series(Light duty)	Engine	4HL1-NA	'05.05~'06.10																																
International	N Series(Light duty)	Engine	4HL1-TC																																	
International	N Series(Light duty)	Engine	4HK1(North America)																																	
International	N Series(Light duty)	Engine	4HK1-TC	EURO2/3																																
International	N Series(Light duty)	Engine	4HK1-TC	EURO4	V	V	V		V																											
International	N Series(Light duty)	Engine	4HK1-TC	EURO5	V	V	V		V													V														
International	N Series(Light duty)	Engine	4HK1-TC	EURO6	V		V		V													V														

Area	Group	Model	Type	System 1	DPD status resetting	Injector ID Code Read	Injector programming	Injector Quantity Trim	Supply Pump Initializtion	Clear adaptation to fast + base	Reset autodetection information	Engine oil distance resetting	Transmission oil distance resetting	Fuel consumption data resetting	Accumulated engine runtime resetting	ENG log data force recording	T/M log data force recording	Accumulated ENG log data clearing	Accumulated T/M log data clearing	Recording DTC data clearing	All accumulation data clearing	Engine oil exchange reset	Injector ID Code Verification	Injector ID Code Resistration	Fuel trim reset	Throttle body relearn	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	TAP CELLS RESET	Program transponder key	Erase transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)
International	N Series(Light duty)	Engine	UreaSCR EURO6		V																															
International	N Series(Light duty)	Engine	4JJ1-TC	EURO2/3																																
International	N Series(Light duty)	Engine	4JJ1-TC	EURO4	V	V	V		V																											
International	N Series(Light duty)	Engine	4JJ1-TC	EURO5	V	V	V		V													V														
International	N Series(Light duty)	Engine	4JJ1-TC (PNLT)																																	
International	N Series(Light duty)	Engine	4HV1(CNG)																																	
International	N Series(Light duty)	Engine	4HF1(CNG)																																	
International	N Series(Light duty)	Engine	4JG2(LPG)																																	
International	N Series(Light duty)	Engine	4HG1(LPG)																																	
International	N Series(Light duty)	Transmission	AT																																	
International	N Series(Light duty)	Transmission	AT(North America)																																	
International	N Series(Light duty)	Transmission	SMOOTHER	SMOOTHER-EX																																
International	N Series(Light duty)	Transmission	SMOOTHER	SMOOTHER-E/AS																																
International	N Series(Light duty)	Chassis	ABS(North America)																																	
International	N Series(Light duty)	Chassis	ABS/ASR																																	
International	N Series(Light duty)	Chassis	ABS EURO6																																	
International	N Series(Light duty)	Chassis	HSA/CFS																																	
International	N Series(Light duty)	Body	BCM									V	V	V	V	V	V	V	V	V	V															
International	N Series(Light duty)	Body	BCM(MIMAMORI)																																	
International	N Series(Light duty)	Body	SRS Airbag																																	
International	N Series(Light duty)	Body	Immobilizer																																	
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	GEN(3Pin)																																
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	EURO2/3																																
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	EURO4	V	V	V		V																											
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	EURO5	V	V	V		V													V														
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	GEN(3Pin)																																
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	GEN(20Pin)																																
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	EURO2/3																																
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	EURO4	V	V	V	V	V																											
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	EURO5	V	V	V	V	V													V														
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	GEN(3Pin)																																
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	GEN(20Pin)																																
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	EURO 2/3																																
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	EURO 4	V	V	V		V																											
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	EURO 5	V	V	V		V													V														
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC	EURO2/3																																
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC	EURO4	V	V	V		V																											

Area	Group	Model	Type	System 1	DPD status resetting	Injector ID Code Read	Injector programming	Injector Quantity Trim	Supply Pump Initializtion	Clear adaptation to fast + base	Reset autodetection information	Engine oil distance resetting	Transmission oil distance resetting	Fuel consumption data resetting	Accumulated engine runtime resetting	ENG log data force recording	T/M log data force recording	Accumulated ENG log data clearing	Accumulated T/M log data clearing	Recording DTC data clearing	All accumulation data clearing	Engine oil exchange reset	Injector ID Code Verification	Injector ID Code Resistration	Fuel trim reset	Throttle body relearn	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	TAP CELLS RESET	Program transponder key	Erase transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC	EURO5	V	V	V		V													V															
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC (PNLT)																																		
International	F/G Series(Medium/Heavy duty)	Engine	6SD1																																		
International	F/G Series(Medium/Heavy duty)	Engine	6UZ1																																		
International	F/G Series(Medium/Heavy duty)	Engine	6WF1		V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-Red4																																		
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-C/Rail		V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	6UZ1-TC																																		
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC	EURO2/3																																	
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC	EURO4	V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC	EURO5	V	V	V	V	V													V															
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC (PNLT)																																		
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-TC	EURO2/3																																	
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-TC	EURO4	V	V	V	V	V																												
International	F/G Series(Medium/Heavy duty)	Engine	10TD1																																		
International	F/G Series(Medium/Heavy duty)	Transmission	AT							V	V																										
International	F/G Series(Medium/Heavy duty)	Transmission	SMOOTHER																																		
International	F/G Series(Medium/Heavy duty)	Chassis	ABS/ASR ADVICS																																		
International	F/G Series(Medium/Heavy duty)	Chassis	ABS/ASR																																		
International	F/G Series(Medium/Heavy duty)	Chassis	ABS/IESC																																		
International	F/G Series(Medium/Heavy duty)	Chassis	Air Suspension																																		
International	F/G Series(Medium/Heavy duty)	Body	BCM									V	V	V	V	V	V	V	V	V	V																
International	F/G Series(Medium/Heavy duty)	Body	BCM(MIMAMORI)																																		
International	F/G Series(Medium/Heavy duty)	Body	SRS Airbag																																		
International	F/G Series(Medium/Heavy duty)	Body	Immobilizer																																		
International	LV/LT Series(Bus)	Engine	4HK1	GEN(3Pin)																																	
International	LV/LT Series(Bus)	Engine	4HK1	EURO2/3																																	
International	LV/LT Series(Bus)	Engine	4HK1	EURO4	V	V	V		V																												
International	LV/LT Series(Bus)	Engine	4HK1	EURO5	V	V	V		V													V															
International	LV/LT Series(Bus)	Engine	6HK1	GEN(3Pin)																																	
International	LV/LT Series(Bus)	Engine	6HK1	GEN(20Pin)																																	
International	LV/LT Series(Bus)	Engine	6HK1	EURO2/3																																	
International	LV/LT Series(Bus)	Engine	6HK1	EURO4	V	V	V	V	V																												
International	LV/LT Series(Bus)	Engine	6HK1	EURO5	V	V	V	V	V													V															
International	LV/LT Series(Bus)	Engine	6HL1	GEN(3Pin)																																	
International	LV/LT Series(Bus)	Engine	6HL1	GEN(20Pin)																																	
International	LV/LT Series(Bus)	Engine	6HL1	EURO 2/3																																	

Area	Group	Model	Type	System 1	DPD status resetting	Injector ID Code Read	Injector programming	Injector Quantity Trim	Supply Pump Initializtion	Clear adaptation to fast + base	Reset autodetection information	Engine oil distance resetting	Transmission oil distance resetting	Fuel consumption data resetting	Accumulated engine runtime resetting	ENG log data force recording	T/M log data force recording	Accumulated ENG log data clearing	Accumulated T/M log data clearing	Recording DTC data clearing	All accumulation data clearing	Engine oil exchange reset	Injector ID Code Verification	Injector ID Code Resistration	Fuel trim reset	Throttle body relearn	Link to ECM to PIM	Injector(s) exchanged	Rail oil pressure sensor exchange	TAP CELLS RESET	Program transponder key	Erase transponder key	Reset Immobilizer	Reset engine controller(Z18XE,Z22SE)	Immobilizer installed(Z18XE,Z22SE)	Engine controller installed(Z18XE,Z22SE)
International	LV/LT Series(Bus)	Engine	6HL1	EURO 4	V	V	V		V																												
International	LV/LT Series(Bus)	Engine	6HL1	EURO 5	V	V	V		V													V															
International	LV/LT Series(Bus)	Engine	4HK1-TC	EURO2/3																																	
International	LV/LT Series(Bus)	Engine	4HK1-TC	EURO4	V	V	V		V																												
International	LV/LT Series(Bus)	Engine	4HK1-TC	EURO5	V	V	V		V													V															
International	LV/LT Series(Bus)	Engine	6UZ1																																		
International	LV/LT Series(Bus)	Engine	6WF1		V	V	V	V	V																												
International	LV/LT Series(Bus)	Engine	6WG1		V	V	V	V	V																												
International	LV/LT Series(Bus)	Engine	6UZ1-TC																																		
International	LV/LT Series(Bus)	Engine	6HK1-TC	EURO2/3																																	
International	LV/LT Series(Bus)	Engine	6HK1-TC	EURO4	V	V	V	V	V																												
International	LV/LT Series(Bus)	Engine	6HK1-TC	EURO5	V	V	V	V	V													V															
International	LV/LT Series(Bus)	Engine	6WG1-TC	EURO2/3																																	
International	LV/LT Series(Bus)	Engine	6WG1-TC	EURO4	V	V	V	V	V																												
International	LV/LT Series(Bus)	Transmission	AT							V	V																										
International	LV/LT Series(Bus)	Transmission	SMOOTHER																																		
International	LV/LT Series(Bus)	Chassis	ABS/ASR																																		
International	LV/LT Series(Bus)	Chassis	ABS/IESC																																		
International	LV/LT Series(Bus)	Chassis	Air Suspension																																		
International	LV/LT Series(Bus)	Body	BCM									V	V	V	V	V	V	V	V	V	V																
International	LV/LT Series(Bus)	Body	BCM(MIMAMORI)																																		
International	LV/LT Series(Bus)	Body	SRS Airbag																																		
International	LV/LT Series(Bus)	Body	Immobilizer																																		

Area	Group	Model	Type	System 1	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Learning Accelerator Data (Programming Force)	Learning Accelerator Data (Programming)	Gearshift, Select stroke learning	clutch free clutch torque position 1 learning	clutch free clutch torque position 1 learning	new clutch disc clutch position learning	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Lateral Acceleration Parameter	ABS installation Status Programming
International	PICKUP TRUCK/SUV	New D-MAX	Diesel Engine	4JK1-TC(2.5)																														
International	PICKUP TRUCK/SUV	New D-MAX	Diesel Engine	4JJ1-TC(3.0)																														
International	PICKUP TRUCK/SUV	New D-MAX	Gasoline Engine	Z32SED																														
International	PICKUP TRUCK/SUV	New D-MAX	Transmission	AT																														
International	PICKUP TRUCK/SUV	New D-MAX	Chassis	ABS																														
International	PICKUP TRUCK/SUV	New D-MAX	Chassis	Transfer case module																														
International	PICKUP TRUCK/SUV	New D-MAX	Body	Immobilizer(BETA)																														
International	PICKUP TRUCK/SUV	New D-MAX	Body	PESS(Passive entry and start system)																														
International	PICKUP TRUCK/SUV	New D-MAX	Body	BCM																														
International	PICKUP TRUCK/SUV	New D-MAX	Body	Meter																														
International	PICKUP TRUCK/SUV	New D-MAX	Body	SRS Airbag																														
International	PICKUP TRUCK/SUV	MU-7	Diesel Engine	4JJ1-TC																														
International	PICKUP TRUCK/SUV	MU-7	Transmission	AT																														
International	PICKUP TRUCK/SUV	MU-7	Chassis	ABS																														
International	PICKUP TRUCK/SUV	MU-7	Body	Immobilizer																														
International	PICKUP TRUCK/SUV	MU-7	Body	BCM																														
International	PICKUP TRUCK/SUV	MU-7	Body	SRS Airbag																														
International	PICKUP TRUCK/SUV	MU-X	Diesel Engine	4JJ1-TC																														
International	PICKUP TRUCK/SUV	MU-X	Transmission	AT																														
International	PICKUP TRUCK/SUV	MU-X	Chassis	ABS																														
International	PICKUP TRUCK/SUV	MU-X	Chassis	Transfer case module																														
International	PICKUP TRUCK/SUV	MU-X	Body	Immobilizer(BETA)																														
International	PICKUP TRUCK/SUV	MU-X	Body	PESS(Passive entry and start system)																														
International	PICKUP TRUCK/SUV	MU-X	Body	BCM																														
International	PICKUP TRUCK/SUV	MU-X	Body	Meter																														
International	PICKUP TRUCK/SUV	MU-X	Body	SRS Airbag																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	6VD1																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.2 L4 SOHC																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.X L4 HV240																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	2.4 LP1 EURO3																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	3.2 V6 6VD1 hitachi																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	3.5 V6 6VE1 hitachi																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Gasoline Engine	V6 Engine																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	2.8L Diesel(LWH)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JX1(3.0 L4)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JH1(2.5)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JH1-TC(3.0 iTD)																														

Area	Group	Model	Type	System 1	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Learning Accelerator Data (Programming Force)	Learning Accelerator Data (Programming)	Gearshift, Select stroke learning	clutch free clutch torque position 1 learning	clutch free clutch torque position 1 learning	new clutch disc clutch position learning	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Lateral Acceleration Parameter	ABS installation Status Programming
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1-TC(Delphi)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1-TC(Transtron)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1(2.5 Delphi)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JK1(2.5 Transtron)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1(3.0 Delphi)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Diesel Engine	4JJ1(3.0 Transtron)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Transmission	AT																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Transmission	AT(6SP)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	ABS/ASR																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	EBCM(Electronic brake control module)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Transfer case module																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Multi-Axis acceleration sensor module																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Chassis	Steering wheel angle sensor module																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(Old type)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(New type)		V	V																											
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Immobilizer(New D-MAX))																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	PIM(Powertrain interface module)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	SRS Airbag																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	BCM																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	BCM(MIMAMORI)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	IPC(Instrument cluster)																														
International	PICKUP TRUCK/SUV	All model(D-MAX/LUV/Frontera/Rodeo)	Body	Aniti theft warning																														
International	N Series(Light duty)	Engine	4HF1																															
International	N Series(Light duty)	Engine	4HE1-TC																															
International	N Series(Light duty)	Engine	4HJ1																															
International	N Series(Light duty)	Engine	4HG1																															
International	N Series(Light duty)	Engine	4JG2																															
International	N Series(Light duty)	Engine	4HL1																															
International	N Series(Light duty)	Engine	4HL1(Vehicle interface module)																															
International	N Series(Light duty)	Engine	4HL1-NA	'04.06~'05.04																														
International	N Series(Light duty)	Engine	4HL1-NA	'05.05~'06.10																														
International	N Series(Light duty)	Engine	4HL1-TC																															
International	N Series(Light duty)	Engine	4HK1(North America)																															
International	N Series(Light duty)	Engine	4HK1-TC	EURO2/3																														
International	N Series(Light duty)	Engine	4HK1-TC	EURO4																														
International	N Series(Light duty)	Engine	4HK1-TC	EURO5																														
International	N Series(Light duty)	Engine	4HK1-TC	EURO6																														

Area	Group	Model	Type	System 1	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Learning Accelerator Data (Programming Force)	Learning Accelerator Data (Programming)	Gearshift, Select stroke learning	clutch free clutch torque position_1 learning	clutch free clutch torque position_1 learning	new clutch disc clutch position learning	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Lateral Acceleration Parameter	ABS installation Status Programming
International	N Series(Light duty)	Engine	UreaSCR_EURO6																														
International	N Series(Light duty)	Engine	4JJ1-TC	EURO2/3																													
International	N Series(Light duty)	Engine	4JJ1-TC	EURO4																													
International	N Series(Light duty)	Engine	4JJ1-TC	EURO5																													
International	N Series(Light duty)	Engine	4JJ1-TC (PNLT)																														
International	N Series(Light duty)	Engine	4HV1(CNG)																						V	V	V	V					
International	N Series(Light duty)	Engine	4HF1(CNG)																										V	V	V		
International	N Series(Light duty)	Engine	4JG2(LPG)																										V	V	V		
International	N Series(Light duty)	Engine	4HG1(LPG)																										V	V	V		
International	N Series(Light duty)	Transmission	AT																														
International	N Series(Light duty)	Transmission	AT(North America)																														
International	N Series(Light duty)	Transmission	SMOOTHER	SMOOTHER-EX										V	V	V	V	V	V	V	V	V	V	V									V
International	N Series(Light duty)	Transmission	SMOOTHER	SMOOTHER-E/AS										V																			
International	N Series(Light duty)	Chassis	ABS(North America)																														
International	N Series(Light duty)	Chassis	ABS/ASR											V																			
International	N Series(Light duty)	Chassis	ABS_EURO6																														
International	N Series(Light duty)	Chassis	HSA/CFS							V	V	V	V	V																			
International	N Series(Light duty)	Body	BCM																														
International	N Series(Light duty)	Body	BCM(MIMAMORI)																														
International	N Series(Light duty)	Body	SRS Airbag											V																			
International	N Series(Light duty)	Body	Immobilizer																														
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	GEN(3Pin)																													
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	EURO2/3										V																			
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	EURO4																													
International	F/G Series(Medium/Heavy duty)	Engine	4HK1	EURO5																													
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	GEN(3Pin)																													
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	GEN(20Pin)																													
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	EURO2/3										V																			
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	EURO4																													
International	F/G Series(Medium/Heavy duty)	Engine	6HK1	EURO5																													
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	GEN(3Pin)																													
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	GEN(20Pin)																													
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	EURO 2/3										V																			
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	EURO 4																													
International	F/G Series(Medium/Heavy duty)	Engine	6HL1	EURO 5																													
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC	EURO2/3										V																			
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC	EURO4																													

Area	Group	Model	Type	System 1	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Learning Accelerator Data (Programming Force)	Learning Accelerator Data (Programming)	Gearshift, Select stroke learning	clutch free clutch torque position_1 learning	clutch free clutch torque position_1 learning	new clutch disc clutch position learning	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Lateral Acceleration Parameter	ABS installation Status Programming
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC	EURO5																														
International	F/G Series(Medium/Heavy duty)	Engine	4HK1-TC (PNLT)																															
International	F/G Series(Medium/Heavy duty)	Engine	6SD1					V	V																									
International	F/G Series(Medium/Heavy duty)	Engine	6UZ1																															
International	F/G Series(Medium/Heavy duty)	Engine	6WF1					V	V																									
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-Red4					V	V																									
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-C/Rail					V	V																									
International	F/G Series(Medium/Heavy duty)	Engine	6UZ1-TC																															
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC	EURO2/3																														
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC	EURO4																														
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC	EURO5																														
International	F/G Series(Medium/Heavy duty)	Engine	6HK1-TC (PNLT)																															
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-TC	EURO2/3																														
International	F/G Series(Medium/Heavy duty)	Engine	6WG1-TC	EURO4																														
International	F/G Series(Medium/Heavy duty)	Engine	10TD1					V	V																									
International	F/G Series(Medium/Heavy duty)	Transmission	AT																															
International	F/G Series(Medium/Heavy duty)	Transmission	SMOOTHER																															
International	F/G Series(Medium/Heavy duty)	Chassis	ABS/ASR ADVICS																															
International	F/G Series(Medium/Heavy duty)	Chassis	ABS/ASR																															
International	F/G Series(Medium/Heavy duty)	Chassis	ABS/IESC											V																				
International	F/G Series(Medium/Heavy duty)	Chassis	Air Suspension																															
International	F/G Series(Medium/Heavy duty)	Body	BCM																															
International	F/G Series(Medium/Heavy duty)	Body	BCM(MIMAMORI)																															
International	F/G Series(Medium/Heavy duty)	Body	SRS Airbag											V																				
International	F/G Series(Medium/Heavy duty)	Body	Immobilizer																															
International	LV/LT Series(Bus)	Engine	4HK1	GEN(3Pin)																														
International	LV/LT Series(Bus)	Engine	4HK1	EURO2/3										V																				
International	LV/LT Series(Bus)	Engine	4HK1	EURO4																														
International	LV/LT Series(Bus)	Engine	4HK1	EURO5																														
International	LV/LT Series(Bus)	Engine	6HK1	GEN(3Pin)																														
International	LV/LT Series(Bus)	Engine	6HK1	GEN(20Pin)																														
International	LV/LT Series(Bus)	Engine	6HK1	EURO2/3										V																				
International	LV/LT Series(Bus)	Engine	6HK1	EURO4																														
International	LV/LT Series(Bus)	Engine	6HK1	EURO5																														
International	LV/LT Series(Bus)	Engine	6HL1	GEN(3Pin)																														
International	LV/LT Series(Bus)	Engine	6HL1	GEN(20Pin)																														
International	LV/LT Series(Bus)	Engine	6HL1	EURO 2/3										V																				

Area	Group	Model	Type	System 1	Program Immobilizer output	Reset immobilizer	Immobilizer link to ECM/PIM(V6 Engine)	Learning Accelerator Data (Programming Force)	Learning Accelerator Data (Programming)	Gearshift, Select stroke learning	clutch free clutch torque position 1 learning	clutch free clutch torque position 1 learning	new clutch disc clutch position learning	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Lateral Acceleration Parameter	ABS installation Status Programming
International	LV/LT Series(Bus)	Engine	6HL1	EURO 4																														
International	LV/LT Series(Bus)	Engine	6HL1	EURO 5																														
International	LV/LT Series(Bus)	Engine	4HK1-TC	EURO2/3										V																				
International	LV/LT Series(Bus)	Engine	4HK1-TC	EURO4																														
International	LV/LT Series(Bus)	Engine	4HK1-TC	EURO5																														
International	LV/LT Series(Bus)	Engine	6UZ1																															
International	LV/LT Series(Bus)	Engine	6WF1																															
International	LV/LT Series(Bus)	Engine	6WG1					V	V																									
International	LV/LT Series(Bus)	Engine	6UZ1-TC																															
International	LV/LT Series(Bus)	Engine	6HK1-TC	EURO2/3																														
International	LV/LT Series(Bus)	Engine	6HK1-TC	EURO4																														
International	LV/LT Series(Bus)	Engine	6HK1-TC	EURO5																														
International	LV/LT Series(Bus)	Engine	6WG1-TC	EURO2/3																														
International	LV/LT Series(Bus)	Engine	6WG1-TC	EURO4																														
International	LV/LT Series(Bus)	Transmission	AT																															
International	LV/LT Series(Bus)	Transmission	SMOOTHER																															
International	LV/LT Series(Bus)	Chassis	ABS/ASR																															
International	LV/LT Series(Bus)	Chassis	ABS/IESC											V																				
International	LV/LT Series(Bus)	Chassis	Air Suspension																															
International	LV/LT Series(Bus)	Body	BCM																															
International	LV/LT Series(Bus)	Body	BCM(MIMAMORI)																															
International	LV/LT Series(Bus)	Body	SRS Airbag											V																				
International	LV/LT Series(Bus)	Body	Immobilizer																															

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
F-Type	2014 ~ 2015	PCM (Powertrain Control Module)	V				V	V																	
F-Type	2014 ~ 2015	TCM (Transmission Control Module)	V																						
F-Type	2014 ~ 2015	GSM (Gear Shift Module)	V																						
F-Type	2014 ~ 2015	ABS (ABS Control Module)	V														V								
F-Type	2014 ~ 2015	RCM (Restraints Control Module)	V																						
F-Type	2014 ~ 2015	OCS (Restraints Occupancy System)	V																						
F-Type	2014 ~ 2015	VIM (Vehicle Immobiliser Module)	V																						
F-Type	2014 ~ 2015	KVM (Keyless Vehicle Module)	V																						
F-Type	2014 ~ 2015	BCM (Body Control Module)	V																						
F-Type	2014 ~ 2015	IPC (Instrument Cluster Control Module)	V																						
F-Type	2014 ~ 2015	PBM (Parking Brake Control Module)	V							V	V	V	V												
F-Type	2014 ~ 2015	PAM (Parking Assist Control Module)	V																						
F-Type	2014 ~ 2015	HCM (Headlamp Control Module)	V																						
F-Type	2014 ~ 2015	HCMB (Headlamp Control Module B)	V																						
F-Type	2014 ~ 2015	ATCM (All Terrain Control Module)	V																						
F-Type	2014 ~ 2015	RDCM (Rear Differential Control Module)	V																						
F-Type	2014 ~ 2015	DDM (Driver's Door Module)	V																						
F-Type	2014 ~ 2015	PDM (Passenger's Door Module)	V																						
F-Type	2014 ~ 2015	RGTM (Rear Gate/Trunk Module)	V																						
F-Type	2014 ~ 2015	DSM (Driver's Seat Module)	V																						
F-Type	2014 ~ 2015	PSM (Passenger's Seat Module)	V																						
F-Type	2014 ~ 2015	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
F-Type	2014 ~ 2015	SODL (Side Object Detection - Left)	V																						
F-Type	2014 ~ 2015	SODR (Side Object Detection - Right)	V																						
F-Type	2014 ~ 2015	CHCM (Chassis Control Module)	V																V	V	V	V	V		
F-Type	2014 ~ 2015	FTCM (Folding Top Control Module)	V																						
F-Type	2014 ~ 2015	FTCMB (Folding Top Control Module B)	V																						
F-Type	2014 ~ 2015	GWM (Gateway Module)	V																						
F-Type	2014 ~ 2015	FCDIM (Front Control/Display Interface Module)	V																						
F-Type	2014 ~ 2015	FCIM (Front Controls Interface Module)	V																						
F-Type	2014 ~ 2015	IPMB (Image Processing Module B)	V																						
F-Type	2014 ~ 2015	ACM (Audio Front Control Module)	V																						
F-Type	2014 ~ 2015	AAM (Audio Amplifier Module)	V																						
F-Type	2014 ~ 2015	DABM (Digital Audio Broadcast Module)	V																						
F-Type	2014 ~ 2015	NCM (Navigation Control Module)	V																						
F-Type	2014 ~ 2015	TVM (Television Module)	V																						
F-Type	2014 ~ 2015	SRM (Satellite Audio Unit Module)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
F-Type	2016 ~	PCM (Powertrain Control Module)	V																						
F-Type	2016 ~	TCM (Transmission Control Module)	V																						
F-Type	2016 ~	ABS (ABS Control Module)	V																						
F-Type	2016 ~	RCM (Restraints Control Module)	V																						
F-Type	2016 ~	IPC (Instrument Cluster Control Module)	V																						
F-Type	2016 ~	PBM (Parking Brake Control Module)	V																						
F-Type	2016 ~	TPM (Tyre Pressure Monitoring System)	V																						
F-Type	2016 ~	BCM (Body Control Module)	V																						
F-Type	2016 ~	GSM (Gear Shift Module)	V																						
F-Type	2016 ~	GWM (Gateway Module)	V																						
F-Type	2016 ~	HCM (Headlamp Control Module)	V																						
F-Type	2016 ~	RDCM (Rear Differential Control Module)	V																						
F-Type	2016 ~	TCCM (Transfer Case Control Module)	V																						
F-Type	2016 ~	VIM (Vehicle Immobiliser Control Module)	V																						
F-Type	2016 ~	ATCM (All Terrain Control Module)	V																						
F-Type	2016 ~	CHCM (Chassis Control Module)	V																						
F-Type	2016 ~	FTCM (Folding Top Control Module)	V																						
F-Type	2016 ~	FTCMB (Folding Top Control Module B)	V																						
F-Type	2016 ~	OCS (Restraints Occupancy System)	V																						
F-Type	2016 ~	PAM (Parking Assist Control Module)	V																						
F-Type	2016 ~	DDM (Driver's Door Module)	V																						
F-Type	2016 ~	DSM (Driver's Seat Module)	V																						
F-Type	2016 ~	PDM (Passenger's Door Module)	V																						
F-Type	2016 ~	PSM (Passenger's Seat Module)	V																						
F-Type	2016 ~	KVM (Keyless Vehicle Module)	V																						
F-Type	2016 ~	RGTM (Rear Gate/Trunk Module)	V																						
F-Type	2016 ~	FCDIM (Front Control/Display Interface Module)	V																						
F-Type	2016 ~	FCIM (Front Controls Interface Module)	V																						
F-Type	2016 ~	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
F-Type	2016 ~	IPMB (Image Processing Module B)	V																						
F-Type	2016 ~	SODL (Side Object Detection - Left)	V																						
F-Type	2016 ~	SODR (Side Object Detection - Right)	V																						
F-Type	2016 ~	AAM (Audio Amplifier Module)	V																						
F-Type	2016 ~	ACM (Audio Front Control Module)	V																						
F-Type	2016 ~	DABM (Digital Audio Broadcast Module)	V																						
F-Type	2016 ~	NCM (Navigation Control Module)	V																						
F-Type	2016 ~	SRM (Satellite Audio Unit Module)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
F-Type	2016 ~	TVM (Television Module)	V																						
S-Type	2005	PBM (Parking Brake Control Module)	V						V																
S-Type	2005	PAM (Parking Aid Control Module)	V																						
S-Type	2005	ADHLS (Headlamp Leveling System)	V																						
S-Type	2005	ARM (Restraints Control Module)	V																						
S-Type	2005	ISM (Intrusion Sensor Module)	V																						
S-Type	2005	DDM (Driver's Door Module)	V																						
S-Type	2005	GEM (General Electronics Control Module)	V																						
S-Type	2005	FETM (Audio Unit)	V																						
S-Type	2005	REM (Rear Entertainment Control Module)	V																						
S-Type	2005	ADRC (Adaptive Damping Ride Control)	V																						
S-Type	2005	DSM (Driver's Seat Module)	V																						
S-Type	2005	NAV (Navigation Control Module)	V																						
S-Type	2006 ~ 2008	ABS (ABS Control Module)	V															V						V	V
S-Type	2006 ~ 2008	PBM (Parking Brake Control Module)	V						V																
S-Type	2006 ~ 2008	PCM (Powertrain Control Module)	V																						
S-Type	2006 ~ 2008	TPM (Tyre Pressure Monitoring System)	V																						
S-Type	2006 ~ 2008	PAM (Parking Aid Control Module)	V																						
S-Type	2006 ~ 2008	ADHLS (Headlamp Leveling System)	V																						
S-Type	2006 ~ 2008	ARM (Restraints Control Module)	V																						
S-Type	2006 ~ 2008	ISM (Intrusion Sensor Module)	V																						
S-Type	2006 ~ 2008	DDM (Driver's Door Module)	V																						
S-Type	2006 ~ 2008	GEM (General Electronics Control Module)	V																						
S-Type	2006 ~ 2008	FETM (Audio Unit)	V																						
S-Type	2006 ~ 2008	REM (Rear Entertainment Control Module)	V																						
S-Type	2006 ~ 2008	ADRC (Adaptive Damping Ride Control)	V																						
S-Type	2006 ~ 2008	DSM (Driver's Seat Module)	V																						
S-Type	2006 ~ 2008	NAV (Navigation Control Module)	V																						
X-Type	2002 ~ 2003	ARM (Restraints Control Module)	V																						
X-Type	2002 ~ 2003	PAM (Parking Aid Control Module)	V																						
X-Type	2002 ~ 2003	ADHLS (Headlamp Leveling System)	V																						
X-Type	2002 ~ 2003	FFH (Fuel Fired Heater Module)	V																						
X-Type	2002 ~ 2003	ISM (Intrusion Sensor Module)	V																						
X-Type	2002 ~ 2003	FETM (Audio Unit)	V																						
X-Type	2002 ~ 2003	GEM (General Electronics Control Module)	V																						
X-Type	2002 ~ 2003	NAV (Navigation Control Module)	V																						
X-Type	2004 ~ 2008	ABS (ABS Control Module)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
X-Type	2004 ~ 2008	DSM (Driver's Seat Module)	V																						
X-Type	2004 ~ 2008	TPM (Tyre Pressure Monitoring System)	V																						
X-Type	2004 ~ 2008	ARM (Restraints Control Module)	V																						
X-Type	2004 ~ 2008	ADHLS (Headlamp Leveling System)	V																						
X-Type	2004 ~ 2008	FFH (Fuel Fired Heater Module)	V																						
X-Type	2004 ~ 2008	PAM (Parking Aid Control Module)	V																						
X-Type	2004 ~ 2008	FETM (Audio Unit)	V																						
X-Type	2004 ~ 2008	GEM (General Electronics Control Module)	V																						
X-Type	2004 ~ 2008	NAV (Navigation Control Module)	V																						
XF	2008 ~ 2009	PCM (Powertrain Control Module)	V				V							V	V	V									
XF	2008 ~ 2009	TCM (Transmission Control Module)	V																						
XF	2008 ~ 2009	GSM (Gear Shift Module)	V																						
XF	2008 ~ 2009	ABS (ABS Control Module)	V														V								
XF	2008 ~ 2009	RCM (Restraints Control Module)	V																						
XF	2008 ~ 2009	OCS (Restraints Occupancy System)	V																						
XF	2008 ~ 2009	VIM (Vehicle Immobiliser Module)	V																						
XF	2008 ~ 2009	KVM (Keyless Vehicle Module)	V																						
XF	2008 ~ 2009	BCM (Body Control Module)	V																						
XF	2008 ~ 2009	BCMB (Body Control Module B)	V																						
XF	2008 ~ 2009	IPC (Instrument Cluster Control Module)	V																						
XF	2008 ~ 2009	ICP (Integrated Control Panel)	V																						
XF	2008 ~ 2009	PBM (Parking Brake Control Module)	V						V																
XF	2008 ~ 2009	PAM (Parking Assist Control Module)	V																						
XF	2008 ~ 2009	HCM (Headlamp Control Module)	V																						
XF	2008 ~ 2009	ADCM (Adaptive Damping Control Module)	V																						
XF	2008 ~ 2009	DDM (Driver's Door Module)	V																						
XF	2008 ~ 2009	PDM (Passenger's Door Module)	V																						
XF	2008 ~ 2009	DSM (Driver's Seat Module)	V																						
XF	2008 ~ 2009	DCSM (Driver's Seat Climate Control Module)	V																						
XF	2008 ~ 2009	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
XF	2008 ~ 2009	SODL (Side Object Detection - Left)	V																						
XF	2008 ~ 2009	SODR (Side Object Detection - Right)	V																						
XF	2008 ~ 2009	TPM (Tyre Pressure Monitoring System)	V																						
XF	2008 ~ 2009	ICS (Impact Classification System)	V																						
XF	2008 ~ 2009	CCM (Adaptive Speed Control Control Module)	V																						
XF	2008 ~ 2009	ICM (Infotainment Control Module)	V																						
XF	2008 ~ 2009	FLR (Forward Looking Radar)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
XF	2008 ~ 2009	FCDIM (Front Control/Display Interface Module)	V																						
XF	2008 ~ 2009	ACM (Audio Front Control Module)	V																						
XF	2008 ~ 2009	AAM (Audio Amplifier Module)	V																						
XF	2008 ~ 2009	DABM (Digital Audio Broadcast Module)	V																						
XF	2008 ~ 2009	NCM (Navigation Control Module)	V																						
XF	2008 ~ 2009	TEL (Cellular Telephone Control Module)	V																						
XF	2008 ~ 2009	TVM (Television Module)	V																						
XF	2008 ~ 2009	SRM (Satellite Audio Unit Module)	V																						
XF	2008 ~ 2009	APIM (Accessory Protocol Interface Module)	V																						
XF	2010 ~ 2011	PCM (Powertrain Control Module)	V				V							V		V									
XF	2010 ~ 2011	TCM (Transmission Control Module)	V																						
XF	2010 ~ 2011	GSM (Gear Shift Module)	V																						
XF	2010 ~ 2011	ABS (ABS Control Module)	V														V								
XF	2010 ~ 2011	RCM (Restraints Control Module)	V																						
XF	2010 ~ 2011	OCS (Restraints Occupancy System)	V																						
XF	2010 ~ 2011	VIM (Vehicle Immobiliser Module)	V																						
XF	2010 ~ 2011	KVM (Keyless Vehicle Module)	V																						
XF	2010 ~ 2011	BCM (Body Control Module)	V																						
XF	2010 ~ 2011	BCMB (Body Control Module B)	V																						
XF	2010 ~ 2011	IPC (Instrument Cluster Control Module)	V																						
XF	2010 ~ 2011	ICP (Integrated Control Panel)	V																						
XF	2010 ~ 2011	PBM (Parking Brake Control Module)	V						V																
XF	2010 ~ 2011	PAM (Parking Assist Control Module)	V																						
XF	2010 ~ 2011	HCM (Headlamp Control Module)	V																						
XF	2010 ~ 2011	ADCM (Adaptive Damping Control Module)	V																						
XF	2010 ~ 2011	RDCM (Rear Differential Control Module)	V																						
XF	2010 ~ 2011	DDM (Driver's Door Module)	V																						
XF	2010 ~ 2011	PDM (Passenger's Door Module)	V																						
XF	2010 ~ 2011	DSM (Driver's Seat Module)	V																						
XF	2010 ~ 2011	DCSM (Driver's Seat Climate Control Module)	V																						
XF	2010 ~ 2011	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
XF	2010 ~ 2011	SODL (Side Object Detection - Left)	V																						
XF	2010 ~ 2011	SODR (Side Object Detection - Right)	V																						
XF	2010 ~ 2011	TPM (Tyre Pressure Monitoring System)	V																						
XF	2010 ~ 2011	ICS (Impact Classification System)	V																						
XF	2010 ~ 2011	CCM (Adaptive Speed Control Control Module)	V																						
XF	2010 ~ 2011	ICM (Infotainment Control Module)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
XF	2010 ~ 2011	FLR (Forward Looking Radar)	V																						
XF	2010 ~ 2011	FCDIM (Front Control/Display Interface Module)	V																						
XF	2010 ~ 2011	ACM (Audio Front Control Module)	V																						
XF	2010 ~ 2011	AAM (Audio Amplifier Module)	V																						
XF	2010 ~ 2011	DABM (Digital Audio Broadcast Module)	V																						
XF	2010 ~ 2011	DACMC (Digital Audio Control Module C)	V																						
XF	2010 ~ 2011	NCM (Navigation Control Module)	V																						
XF	2010 ~ 2011	TEL (Cellular Telephone Control Module)	V																						
XF	2010 ~ 2011	TVM (Television Module)	V																						
XF	2010 ~ 2011	SRM (Satellite Audio Unit Module)	V																						
XF	2010 ~ 2011	APIM (Accessory Protocol Interface Module)	V																						
XF	2012	PCM (Powertrain Control Module)	V				V							V		V									
XF	2012	TCM (Transmission Control Module)	V																						
XF	2012	GSM (Gear Shift Module)	V																						
XF	2012	ABS (ABS Control Module)	V														V	V							
XF	2012	RCM (Restraints Control Module)	V																						
XF	2012	OCS (Restraints Occupancy System)	V																						
XF	2012	VIM (Vehicle Immobiliser Module)	V																						
XF	2012	KVM (Keyless Vehicle Module)	V																						
XF	2012	BCM (Body Control Module)	V																						
XF	2012	BCMB (Body Control Module B)	V																						
XF	2012	IPC (Instrument Cluster Control Module)	V																						
XF	2012	PBM (Parking Brake Control Module)	V						V																
XF	2012	PAM (Parking Assist Control Module)	V																						
XF	2012	HCM (Headlamp Control Module)	V																						
XF	2012	HCMB (Headlamp Control Module B)	V																						
XF	2012	ADCM (Adaptive Damping Control Module)	V																						
XF	2012	RDCM (Rear Differential Control Module)	V																						
XF	2012	DDM (Driver's Door Module)	V																						
XF	2012	PDM (Passenger's Door Module)	V																						
XF	2012	SPMA (Seatbelt Pretensioner Control Module A)	V																						
XF	2012	SPMB (Seatbelt Pretensioner Control Module B)	V																						
XF	2012	DSM (Driver's Seat Module)	V																						
XF	2012	PSM (Passenger's Seat Module)	V																						
XF	2012	DCSM (Driver's Seat Climate Control Module)	V																						
XF	2012	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
XF	2012	SODL (Side Object Detection - Left)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
XF	2012	SODR (Side Object Detection - Right)	V																						
XF	2012	TPM (Tyre Pressure Monitoring System)	V																						
XF	2012	ICS (Impact Classification System)	V																						
XF	2012	GWM (Gateway Module)	V																						
XF	2012	CCM (Adaptive Speed Control Control Module)	V																						
XF	2012	FCDIM (Front Control/Display Interface Module)	V																						
XF	2012	FCIMB (Front Controls Interface Module B)	V																						
XF	2012	ACM (Audio Front Control Module)	V																						
XF	2012	AAM (Audio Amplifier Module)	V																						
XF	2012	DABM (Digital Audio Broadcast Module)	V																						
XF	2012	NCM (Navigation Control Module)	V																						
XF	2012	TVM (Television Module)	V																						
XF	2012	SRM (Satellite Audio Unit Module)	V																						
XF	2013 ~ 2015	PCM (Powertrain Control Module)	V				V							V		V									
XF	2013 ~ 2015	TCM (Transmission Control Module)	V																						
XF	2013 ~ 2015	TCCM (Transfer Case Control Module)	V																						
XF	2013 ~ 2015	GSM (Gear Shift Module)	V																						
XF	2013 ~ 2015	ABS (ABS Control Module)	V														V	V							
XF	2013 ~ 2015	RCM (Restraints Control Module)	V																						
XF	2013 ~ 2015	OCS (Restraints Occupancy System)	V																						
XF	2013 ~ 2015	VIM (Vehicle Immobiliser Module)	V																						
XF	2013 ~ 2015	KVM (Keyless Vehicle Module)	V																						
XF	2013 ~ 2015	BCM (Body Control Module)	V																						
XF	2013 ~ 2015	BCMB (Body Control Module B)	V																						
XF	2013 ~ 2015	IPC (Instrument Cluster Control Module)	V					V																	
XF	2013 ~ 2015	PBM (Parking Brake Control Module)	V						V																
XF	2013 ~ 2015	PAM (Parking Assist Control Module)	V																						
XF	2013 ~ 2015	HCM (Headlamp Control Module)	V																						
XF	2013 ~ 2015	HCMB (Headlamp Control Module B)	V																						
XF	2013 ~ 2015	ADCM (Adaptive Damping Control Module)	V																						
XF	2013 ~ 2015	RDCM (Rear Differential Control Module)	V																						
XF	2013 ~ 2015	DDM (Driver's Door Module)	V																						
XF	2013 ~ 2015	PDM (Passenger's Door Module)	V																						
XF	2013 ~ 2015	RGTM (Rear Gate/Trunk Module)	V																						
XF	2013 ~ 2015	SPMA (Seatbelt Pretensioner Control Module A)	V																						
XF	2013 ~ 2015	SPMB (Seatbelt Pretensioner Control Module B)	V																						
XF	2013 ~ 2015	DSM (Driver's Seat Module)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
XF	2013 ~ 2015	PSM (Passenger's Seat Module)	V																						
XF	2013 ~ 2015	DCSM (Driver's Seat Climate Control Module)	V																						
XF	2013 ~ 2015	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
XF	2013 ~ 2015	SODL (Side Object Detection - Left)	V																						
XF	2013 ~ 2015	SODR (Side Object Detection - Right)	V																						
XF	2013 ~ 2015	CHCM (Chassis Control Module)	V																V	V	V	V	V		
XF	2013 ~ 2015	TPM (Tyre Pressure Monitoring System)	V																						
XF	2013 ~ 2015	GWM (Gateway Module)	V																						
XF	2013 ~ 2015	CCM (Adaptive Speed Control Control Module)	V																						
XF	2013 ~ 2015	FCDIM (Front Control/Display Interface Module)	V																						
XF	2013 ~ 2015	FCIMB (Front Controls Interface Module B)	V																						
XF	2013 ~ 2015	ACM (Audio Front Control Module)	V																						
XF	2013 ~ 2015	AAM (Audio Amplifier Module)	V																						
XF	2013 ~ 2015	DABM (Digital Audio Broadcast Module)	V																						
XF	2013 ~ 2015	NCM (Navigation Control Module)	V																						
XF	2013 ~ 2015	TVM (Television Module)	V																						
XF	2013 ~ 2015	SRM (Satellite Audio Unit Module)	V																						
XF	2016 ~	PCM (Powertrain Control Module)	V																						
XF	2016 ~	TCM (Transmission Control Module)	V																						
XF	2016 ~	ABS (ABS Control Module)	V																						
XF	2016 ~	RCM (Restraints Control Module)	V																						
XF	2016 ~	IPC (Instrument Cluster Control Module)	V																						
XF	2016 ~	TPM (Tyre Pressure Monitoring System)	V																						
XF	2016 ~	BCM (Body Control Module)	V																						
XF	2016 ~	CCM (Adaptive Speed Control Control Module)	V																						
XF	2016 ~	GSM (Gear Shift Module)	V																						
XF	2016 ~	GWM (Gateway Module)	V																						
XF	2016 ~	OCS (Restraints Occupancy System)	V																						
XF	2016 ~	TCCM (Transfer Case Control Module)	V																						
XF	2016 ~	VIM (Vehicle Immobiliser Module)	V																						
XF	2016 ~	ATCM (All Terrain Control Module)	V																						
XF	2016 ~	CHCM (Chassis Control Module)	V																						
XF	2016 ~	PAM (Parking Assist Control Module)	V																						
XF	2016 ~	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
XF	2016 ~	IPMB (Image Processing Module B)	V																						
XF	2016 ~	RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)	V																						
XF	2016 ~	SODL (Side Object Detection - Left)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
XF	2016 ~	SODR (Side Object Detection - Right)	V																						
XF	2016 ~	DDM (Driver's Door Module)	V																						
XF	2016 ~	DSM (Driver's Seat Module)	V																						
XF	2016 ~	PDM (Passenger's Door Module)	V																						
XF	2016 ~	PSM (Passenger's Seat Module)	V																						
XF	2016 ~	KVM (Keyless Vehicle Module)	V																						
XF	2016 ~	RGTM (Rear Gate/Trunk Module)	V																						
XJ Series	2004 ~ 2005	ARM (Restraints Control Module)	V																						
XJ Series	2004 ~ 2005	PAM (Parking Aid Control Module)	V																						
XJ Series	2004 ~ 2005	ADHLS_L (Left Lighting Control Module)	V																						
XJ Series	2004 ~ 2005	ADHLS_R (Right Lighting Control Module)	V																						
XJ Series	2004 ~ 2005	ISM (Intrusion Sensor Module)	V																						
XJ Series	2004 ~ 2005	DDM (Driver's Door Module)	V																						
XJ Series	2004 ~ 2005	EPB (Electronic Parking Brake)	V																						
XJ Series	2004 ~ 2005	GEM (General Electronics Control Module)	V																						
XJ Series	2004 ~ 2005	FETM (Audio Unit)	V																						
XJ Series	2004 ~ 2005	REM (Rear Entertainment Control Module)	V																						
XJ Series	2004 ~ 2005	DSM (Driver's Seat Module)	V																						
XJ Series	2004 ~ 2005	NAV (Navigation Control Module)	V																						
XJ Series	2004 ~ 2005	RSM (Rear Seat Control Module)	V																						
XJ Series	2006 ~ 2007	PCM (Powertrain Control Module)	V				V																		
XJ Series	2006 ~ 2007	ABS (ABS Control Module)	V																						
XJ Series	2006 ~ 2007	PBM (Parking Brake Control Module)	V						V																
XJ Series	2006 ~ 2007	TPM (Tyre Pressure Monitoring System)	V																						
XJ Series	2006 ~ 2007	PAM (Parking Aid Control Module)	V																						
XJ Series	2006 ~ 2007	ADHLS_L (Left Lighting Control Module)	V																						
XJ Series	2006 ~ 2007	ADHLS_R (Right Lighting Control Module)	V																						
XJ Series	2006 ~ 2007	ARM (Restraints Control Module)	V																						
XJ Series	2006 ~ 2007	ISM (Intrusion Sensor Module)	V																						
XJ Series	2006 ~ 2007	DDM (Driver's Door Module)	V																						
XJ Series	2006 ~ 2007	GEM (General Electronics Control Module)	V																						
XJ Series	2006 ~ 2007	FETM (Audio Unit)	V																						
XJ Series	2006 ~ 2007	REM (Rear Entertainment Control Module)	V																						
XJ Series	2006 ~ 2007	DSM (Driver's Seat Module)	V																						
XJ Series	2006 ~ 2007	NAV (Navigation Control Module)	V																						
XJ Series	2006 ~ 2007	RSM (Rear Seat Control Module)	V																						
XJ Series	2008 ~ 2009	PCM (Powertrain Control Module)	V				V																		

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
XJ Series	2008 ~ 2009	ABS (ABS Control Module)	V															V						V	V
XJ Series	2008 ~ 2009	PBM (Parking Brake Control Module)	V						V																
XJ Series	2008 ~ 2009	DCSM (Driver's Seat Climate Control Module)	V																						
XJ Series	2008 ~ 2009	TPM (Tyre Pressure Monitoring System)	V																						
XJ Series	2008 ~ 2009	PAM (Parking Aid Control Module)	V																						
XJ Series	2008 ~ 2009	ADHLS_L (Left Lighting Control Module)	V																						
XJ Series	2008 ~ 2009	ADHLS_R (Right Lighting Control Module)	V																						
XJ Series	2008 ~ 2009	ARM (Restraints Control Module)	V																						
XJ Series	2008 ~ 2009	ISM (Intrusion Sensor Module)	V																						
XJ Series	2008 ~ 2009	DDM (Driver's Door Module)	V																						
XJ Series	2008 ~ 2009	GEM (General Electronics Control Module)	V																						
XJ Series	2008 ~ 2009	FETM (Audio Unit)	V																						
XJ Series	2008 ~ 2009	REM (Rear Entertainment Control Module)	V																						
XJ Series	2008 ~ 2009	DSM (Driver's Seat Module)	V																						
XJ Series	2008 ~ 2009	NAV (Navigation Control Module)	V																						
XJ Series	2008 ~ 2009	RSM (Rear Seat Control Module)	V																						
XJ Series	2010 ~ 2012	PCM (Powertrain Control Module)	V				V							V		V									
XJ Series	2010 ~ 2012	TCM (Transmission Control Module)	V																						
XJ Series	2010 ~ 2012	GSM (Gear Shift Module)	V																						
XJ Series	2010 ~ 2012	ABS (ABS Control Module)	V														V								
XJ Series	2010 ~ 2012	RCM (Restraints Control Module)	V																						
XJ Series	2010 ~ 2012	OCS (Restraints Occupancy System)	V																						
XJ Series	2010 ~ 2012	VIM (Vehicle Immobiliser Module)	V																						
XJ Series	2010 ~ 2012	KVM (Keyless Vehicle Module)	V																						
XJ Series	2010 ~ 2012	BCM (Body Control Module)	V																						
XJ Series	2010 ~ 2012	IPC (Instrument Cluster Control Module)	V					V																	
XJ Series	2010 ~ 2012	PBM (Parking Brake Control Module)	V						V																
XJ Series	2010 ~ 2012	PAM (Parking Assist Control Module)	V																						
XJ Series	2010 ~ 2012	HCM (Headlamp Control Module)	V																						
XJ Series	2010 ~ 2012	HCMB (Headlamp Control Module B)	V																						
XJ Series	2010 ~ 2012	ADCM (Adaptive Damping Control Module)	V																						
XJ Series	2010 ~ 2012	RDCM (Rear Differential Control Module)	V																						
XJ Series	2010 ~ 2012	DDM (Driver's Door Module)	V																						
XJ Series	2010 ~ 2012	PDM (Passenger's Door Module)	V																						
XJ Series	2010 ~ 2012	RGTM (Rear Gate/Trunk Module)	V																						
XJ Series	2010 ~ 2012	SPMA (Seatbelt Pretensioner Control Module A)	V																						
XJ Series	2010 ~ 2012	SPMB (Seatbelt Pretensioner Control Module B)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
XJ Series	2010 ~ 2012	DSM (Driver's Seat Module)	V																						
XJ Series	2010 ~ 2012	PSM (Passenger's Seat Module)	V																						
XJ Series	2010 ~ 2012	RLSM (Rear Left Seat Module)	V																						
XJ Series	2010 ~ 2012	RRSM (Rear Right Seat Module)	V																						
XJ Series	2010 ~ 2012	DCSM (Driver's Seat Climate Control Module)	V																						
XJ Series	2010 ~ 2012	RDCSM (Rear Seat Climate Control Module)	V																						
XJ Series	2010 ~ 2012	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
XJ Series	2010 ~ 2012	RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)	V																						
XJ Series	2010 ~ 2012	SODL (Side Object Detection - Left)	V																						
XJ Series	2010 ~ 2012	SODR (Side Object Detection - Right)	V																						
XJ Series	2010 ~ 2012	RLM (Ride Level Control Module)	V																						
XJ Series	2010 ~ 2012	CCM (Adaptive Speed Control Control Module)	V																						
XJ Series	2010 ~ 2012	FCDIM (Front Control/Display Interface Module)	V																						
XJ Series	2010 ~ 2012	FCIMB (Front Controls Interface Module B)	V																						
XJ Series	2010 ~ 2012	ACM (Audio Front Control Module)	V																						
XJ Series	2010 ~ 2012	AAM (Audio Amplifier Module)	V																						
XJ Series	2010 ~ 2012	DABM (Digital Audio Broadcast Module)	V																						
XJ Series	2010 ~ 2012	NCM (Navigation Control Module)	V																						
XJ Series	2010 ~ 2012	REM (Rear Entertainment Control Module)	V																						
XJ Series	2010 ~ 2012	TVM (Television Module)	V																						
XJ Series	2010 ~ 2012	SRM (Satellite Audio Unit Module)	V																						
XJ Series	2013 ~ 2015	PCM (Powertrain Control Module)	V				V							V		V									
XJ Series	2013 ~ 2015	TCM (Transmission Control Module)	V																						
XJ Series	2013 ~ 2015	TCCM (Transfer Case Control Module)	V																						
XJ Series	2013 ~ 2015	GSM (Gear Shift Module)	V																						
XJ Series	2013 ~ 2015	ABS (ABS Control Module)	V														V	V							
XJ Series	2013 ~ 2015	RCM (Restraints Control Module)	V																						
XJ Series	2013 ~ 2015	OCS (Restraints Occupancy System)	V																						
XJ Series	2013 ~ 2015	VIM (Vehicle Immobiliser Module)	V																						
XJ Series	2013 ~ 2015	KVM (Keyless Vehicle Module)	V																						
XJ Series	2013 ~ 2015	BCM (Body Control Module)	V																						
XJ Series	2013 ~ 2015	IPC (Instrument Cluster Control Module)	V					V																	
XJ Series	2013 ~ 2015	PBM (Parking Brake Control Module)	V						V																
XJ Series	2013 ~ 2015	PAM (Parking Assist Control Module)	V																						
XJ Series	2013 ~ 2015	HCM (Headlamp Control Module)	V																						
XJ Series	2013 ~ 2015	HCMB (Headlamp Control Module B)	V																						
XJ Series	2013 ~ 2015	RDCM (Rear Differential Control Module)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
XJ Series	2013 ~ 2015	DDM (Driver's Door Module)	V																						
XJ Series	2013 ~ 2015	PDM (Passenger's Door Module)	V																						
XJ Series	2013 ~ 2015	RGTM (Rear Gate/Trunk Module)	V																						
XJ Series	2013 ~ 2015	DSM (Driver's Seat Module)	V																						
XJ Series	2013 ~ 2015	PSM (Passenger's Seat Module)	V																						
XJ Series	2013 ~ 2015	RLSM (Rear Left Seat Module)	V																						
XJ Series	2013 ~ 2015	RRSM (Rear Right Seat Module)	V																						
XJ Series	2013 ~ 2015	DCSM (Driver's Seat Climate Control Module)	V																						
XJ Series	2013 ~ 2015	RDCSM (Rear Seat Climate Control Module)	V																						
XJ Series	2013 ~ 2015	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
XJ Series	2013 ~ 2015	RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)	V																						
XJ Series	2013 ~ 2015	SODL (Side Object Detection - Left)	V																						
XJ Series	2013 ~ 2015	SODR (Side Object Detection - Right)	V																						
XJ Series	2013 ~ 2015	CHCM (Chassis Control Module)	V																V	V	V	V	V		
XJ Series	2013 ~ 2015	GWM (Gateway Module)	V																						
XJ Series	2013 ~ 2015	CCM (Adaptive Speed Control Control Module)	V																						
XJ Series	2013 ~ 2015	FCDIM (Front Control/Display Interface Module)	V																						
XJ Series	2013 ~ 2015	FCIMB (Front Controls Interface Module B)	V																						
XJ Series	2013 ~ 2015	ACM (Audio Front Control Module)	V																						
XJ Series	2013 ~ 2015	AAM (Audio Amplifier Module)	V																						
XJ Series	2013 ~ 2015	DABM (Digital Audio Broadcast Module)	V																						
XJ Series	2013 ~ 2015	NCM (Navigation Control Module)	V																						
XJ Series	2013 ~ 2015	REM (Rear Entertainment Control Module)	V																						
XJ Series	2013 ~ 2015	TVM (Television Module)	V																						
XJ Series	2013 ~ 2015	SRM (Satellite Audio Unit Module)	V																						
XJ Series	2016 ~	PCM (Powertrain Control Module)	V																						
XJ Series	2016 ~	TCM (Transmission Control Module)	V																						
XJ Series	2016 ~	ABS (ABS Control Module)	V																						
XJ Series	2016 ~	RCM (Restraints Control Module)	V																						
XJ Series	2016 ~	IPC (Instrument Cluster Control Module)	V																						
XJ Series	2016 ~	PBM (Parking Brake Control Module)	V																						
XJ Series	2016 ~	TPM (Tyre Pressure Monitoring System)	V																						
XJ Series	2016 ~	BCM (Body Control Module)	V																						
XJ Series	2016 ~	CCM (Adaptive Speed Control Control Module)	V																						
XJ Series	2016 ~	GSM (Gear Shift Module)	V																						
XJ Series	2016 ~	GWM (Gateway Module)	V																						
XJ Series	2016 ~	HCM (Headlamp Control Module)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
XJ Series	2016 ~	OCS (Restraints Occupancy System)	V																						
XJ Series	2016 ~	RDCM (Rear Differential Control Module)	V																						
XJ Series	2016 ~	TCCM (Transfer Case Control Module)	V																						
XJ Series	2016 ~	VIM (Vehicle Immobiliser Module)	V																						
XJ Series	2016 ~	CHCM (Chassis Control Module)	V																						
XJ Series	2016 ~	PAM (Parking Assist Control Module)	V																						
XJ Series	2016 ~	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
XJ Series	2016 ~	IPMB (Image Processing Module B)	V																						
XJ Series	2016 ~	RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)	V																						
XJ Series	2016 ~	SODL (Side Object Detection - Left)	V																						
XJ Series	2016 ~	SODR (Side Object Detection - Right)	V																						
XJ Series	2016 ~	DDM (Driver's Door Module)	V																						
XJ Series	2016 ~	DSM (Driver's Seat Module)	V																						
XJ Series	2016 ~	PDM (Passenger's Door Module)	V																						
XJ Series	2016 ~	PSM (Passenger's Seat Module)	V																						
XJ Series	2016 ~	KVM (Keyless Vehicle Module)	V																						
XJ Series	2016 ~	RGTM (Rear Gate/Trunk Module)	V																						
XJ Series	2016 ~	RLSM (Rear Left Seat Module)	V																						
XJ Series	2016 ~	RRSM (Rear Right Seat Module)	V																						
XK Series	2003 ~ 2006	ARM (Restraints Control Module)	V																						
XK Series	2003 ~ 2006	PAM (Parking Aid Control Module)	V																						
XK Series	2003 ~ 2006	ADHLS_L (Left Lighting Control Module)	V																						
XK Series	2003 ~ 2006	ADHLS_R (Right Lighting Control Module)	V																						
XK Series	2003 ~ 2006	KTM (Key Transponder Module)	V																						
XK Series	2003 ~ 2006	BPM (Body Processor Module)	V																						
XK Series	2003 ~ 2006	DDM (Driver's Door Module)	V																						
XK Series	2003 ~ 2006	DSM (Driver's Seat Module)	V																						
XK Series	2003 ~ 2006	PDM (Passenger's Door Module)	V																						
XK Series	2003 ~ 2006	PSM (Passenger's Seat Module)	V																						
XK Series	2003 ~ 2006	SLM (Security Locking Module)	V																						
XK Series	2003 ~ 2006	DHM (Driver's head Restraint Module)	V																						
XK Series	2003 ~ 2006	PHM (Passenger's Head Restraint Module)	V																						
XK Series	2007 ~ 2009	PCM (Powertrain Control Module)	V																						
XK Series	2007 ~ 2009	TCM (Transmission Control Module)	V																						
XK Series	2007 ~ 2009	ABS (ABS Control Module)	V																						
XK Series	2007 ~ 2009	RCM (Restraints Control Module)	V																						
XK Series	2007 ~ 2009	VIM (Vehicle Immobiliser Module)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
XK Series	2007 ~ 2009	KVM (Keyless Vehicle Module)	V																						
XK Series	2007 ~ 2009	BCM (Body Control Module)	V																						
XK Series	2007 ~ 2009	BCMB (Body Control Module B)	V																						
XK Series	2007 ~ 2009	IPC (Instrument Cluster Control Module)	V																						
XK Series	2007 ~ 2009	ICP (Integrated Control Panel)	V																						
XK Series	2007 ~ 2009	PBM (Parking Brake Control Module)	V						V																
XK Series	2007 ~ 2009	PAM (Parking Assist Control Module)	V																						
XK Series	2007 ~ 2009	HCM (Headlamp Control Module)	V																						
XK Series	2007 ~ 2009	ADCM (Adaptive Damping Control Module)	V																						
XK Series	2007 ~ 2009	DDM (Driver's Door Module)	V																						
XK Series	2007 ~ 2009	PDM (Passenger's Door Module)	V																						
XK Series	2007 ~ 2009	DSM (Driver's Seat Module)	V																						
XK Series	2007 ~ 2009	PSM (Passenger's Seat Module)	V																						
XK Series	2007 ~ 2009	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
XK Series	2007 ~ 2009	TPM (Tyre Pressure Monitoring System)	V																						
XK Series	2007 ~ 2009	ICS (Impact Classification System)	V																						
XK Series	2007 ~ 2009	FTCM (Folding Top Control Module)	V																						
XK Series	2007 ~ 2009	CCM (Adaptive Speed Control Control Module)	V																						
XK Series	2007 ~ 2009	ICM (Infotainment Control Module)	V																						
XK Series	2007 ~ 2009	FLR (Forward Looking Radar)	V																						
XK Series	2007 ~ 2009	FCDIM (Front Control/Display Interface Module)	V																						
XK Series	2007 ~ 2009	ACM (Audio Front Control Module)	V																						
XK Series	2007 ~ 2009	AAM (Audio Amplifier Module)	V																						
XK Series	2007 ~ 2009	NCM (Navigation Control Module)	V																						
XK Series	2007 ~ 2009	SRM (Satellite Audio Unit Module)	V																						
XK Series	2007 ~ 2009	APIM (Accessory Protocol Interface Module)	V																						
XK Series	2007 ~ 2009	BPM (Body Processor Module)	V																						
XK Series	2010 ~ 2015	PCM (Powertrain Control Module)	V				V																		
XK Series	2010 ~ 2015	TCM (Transmission Control Module)	V																						
XK Series	2010 ~ 2015	GSM (Gear Shift Module)	V																						
XK Series	2010 ~ 2015	ABS (ABS Control Module)	V														V								
XK Series	2010 ~ 2015	RCM (Restraints Control Module)	V																						
XK Series	2010 ~ 2015	OCS (Restraints Occupancy System)	V																						
XK Series	2010 ~ 2015	VIM (Vehicle Immobiliser Module)	V																						
XK Series	2010 ~ 2015	KVM (Keyless Vehicle Module)	V																						
XK Series	2010 ~ 2015	BCM (Body Control Module)	V																						
XK Series	2010 ~ 2015	BCMB (Body Control Module B)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
XK Series	2010 ~ 2015	IPC (Instrument Cluster Control Module)	V																						
XK Series	2010 ~ 2015	ICP (Integrated Control Panel)	V																						
XK Series	2010 ~ 2015	PBM (Parking Brake Control Module)	V						V																
XK Series	2010 ~ 2015	PAM (Parking Assist Control Module)	V																						
XK Series	2010 ~ 2015	HCM (Headlamp Control Module)	V																						
XK Series	2010 ~ 2015	ADCM (Adaptive Damping Control Module)	V																						
XK Series	2010 ~ 2015	RDCM (Rear Differential Control Module)	V																						
XK Series	2010 ~ 2015	DDM (Driver's Door Module)	V																						
XK Series	2010 ~ 2015	PDM (Passenger's Door Module)	V																						
XK Series	2010 ~ 2015	DSM (Driver's Seat Module)	V																						
XK Series	2010 ~ 2015	PSM (Passenger's Seat Module)	V																						
XK Series	2010 ~ 2015	DCSM (Driver's Seat Climate Control Module)	V																						
XK Series	2010 ~ 2015	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
XK Series	2010 ~ 2015	TPM (Tyre Pressure Monitoring System)	V																						
XK Series	2010 ~ 2015	ICS (Impact Classification System)	V																						
XK Series	2010 ~ 2015	FTCM (Folding Top Control Module)	V																						
XK Series	2010 ~ 2015	CCM (Adaptive Speed Control Control Module)	V																						
XK Series	2010 ~ 2015	ICM (Infotainment Control Module)	V																						
XK Series	2010 ~ 2015	FLR (Forward Looking Radar)	V																						
XK Series	2010 ~ 2015	FCDIM (Front Control/Display Interface Module)	V																						
XK Series	2010 ~ 2015	ACM (Audio Front Control Module)	V																						
XK Series	2010 ~ 2015	AAM (Audio Amplifier Module)	V																						
XK Series	2010 ~ 2015	DABM (Digital Audio Broadcast Module)	V																						
XK Series	2010 ~ 2015	DACMC (Digital Audio Control Module C)	V																						
XK Series	2010 ~ 2015	NCM (Navigation Control Module)	V																						
XK Series	2010 ~ 2015	TEL (Cellular Telephone Control Module)	V																						
XK Series	2010 ~ 2015	SRM (Satellite Audio Unit Module)	V																						
XK Series	2010 ~ 2015	APIM (Accessory Protocol Interface Module)	V																						
XE	2016 ~	PCM (Powertrain Control Module)	V																						
XE	2016 ~	TCM (Transmission Control Module)	V																						
XE	2016 ~	ABS (ABS Control Module)	V																						
XE	2016 ~	RCM (Restraints Control Module)	V																						
XE	2016 ~	IPC (Instrument Cluster Control Module)	V																						
XE	2016 ~	TPM (Tyre Pressure Monitoring System)	V																						
XE	2016 ~	BCM (Body Control Module)	V																						
XE	2016 ~	CCM (Adaptive Speed Control Control Module)	V																						
XE	2016 ~	GSM (Gear Shift Module)	V																						

vehicle	Year	System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	Oil Service Counter reset	Service Interval Reset	Parking brake release to the service position	Parking brake pad replacement - Release to service position	Parking brake pad replacement - Exit maintenance mode application	Longitudinal accelerometer calibration	Parking brake activation	Diesel particulate filter replacement	Diesel particulate filter fuel related component replacement	Diesel Particulate Filter Dynamic Regeneration	Brake bleed	Yaw rate sensor calibration	Set/Un-set air suspension manufacturing/freeze mode	Set/Un-set air suspension geometry set-up	Set/Un-set air suspension tight tolerance mode(headlamp setting)	Air-suspension deflation	Air-suspension inflation	Lateral accelerometer calibration	Pressure sensor calibration
XE	2016 ~	GWM (Gateway Module)	V																						
XE	2016 ~	OCS (Restraints Occupancy System)	V																						
XE	2016 ~	VIM (Vehicle Immobiliser Module)	V																						
XE	2016 ~	ATCM (All Terrain Control Module)	V																						
XE	2016 ~	CHCM (Chassis Control Module)	V																						
XE	2016 ~	PAM (Parking Assist Control Module)	V																						
XE	2016 ~	DDM (Driver's Door Module)	V																						
XE	2016 ~	DSM (Driver's Seat Module)	V																						
XE	2016 ~	PDM (Passenger's Door Module)	V																						
XE	2016 ~	KVM (Keyless Vehicle Module)	V																						
XE	2016 ~	RGTM (Rear Gate/Trunk Module)	V																						
XE	2016 ~	FCDIM (Front Control/Display Interface Module)	V																						
XE	2016 ~	FCIM (Front Controls Interface Module)	V																						
XE	2016 ~	HVAC (Heating Ventilation and Air Conditioning Control Module)	V																						
XE	2016 ~	SODL (Side Object Detection - Left)	V																						
XE	2016 ~	SODR (Side Object Detection - Right)	V																						
XE	2016 ~	AAM (Audio Amplifier Module)	V																						
XE	2016 ~	ACM (Audio Front Control Module)	V																						
XE	2016 ~	DABM (Digital Audio Broadcast Module)	V																						
XE	2016 ~	NCM (Navigation Control Module)	V																						
XE	2016 ~	SRM (Satellite Audio Unit Module)	V																						
XE	2016 ~	TVM (Television Module)	V																						

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
General(CAN Bus)	ALL	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
General(CAN Bus)	ALL	ABS (Anti Lock Brake System)	V	V	V	V																																								V	V	V	V
General(CAN Bus)	ALL	ACC (Adaptive Cruise Control)	V			V																																											
General(CAN Bus)	ALL	ADCM (Adaptive Damper Control Module)	V			V																																											
General(CAN Bus)	ALL	AFLS (Adaptive Front Light System)	V			V																																											
General(CAN Bus)	ALL	AHBM (Automatic High Beam)	V			V																																											
General(CAN Bus)	ALL	AMP (Audio)	V	V		V																																											
General(CAN Bus)	ALL	BCM (Body Control Module)	V			V																																											
General(CAN Bus)	ALL	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																											
General(CAN Bus)	ALL	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																											
General(CAN Bus)	ALL	CGW (Central Gateway)	V	V	V	V																																											
General(CAN Bus)	ALL	DDM (Drivers Door Module)	V	V	V	V																																											
General(CAN Bus)	ALL	DTCM (Drive Train Control Module)	V			V																																											
General(CAN Bus)	ALL	EDM (Electronic Damper Module)	V			V																																											
General(CAN Bus)	ALL	EOM (Electric Overhead Module)	V	V	V	V																																											
General(CAN Bus)	ALL	EPB (Electrical Parking Brake)	V	V		V																																											
General(CAN Bus)	ALL	EPS (Electric Power Steering)	V			V																																											
General(CAN Bus)	ALL	ESM (Electronic Shifter Module)	V			V																																											
General(CAN Bus)	ALL	FFCM (Front Facing Camera Module)	V	V	V	V																																											
General(CAN Bus)	ALL	HFM (Hands Free Module)	V	V	V	V																																											
General(CAN Bus)	ALL	HSM (Heated Seat Module)	V			V																																											
General(CAN Bus)	ALL	HVAC (Heat Vent A/C)	V	V	V	V																																											
General(CAN Bus)	ALL	ICS (Integrated Center Stack)	V			V																																											
General(CAN Bus)	ALL	IPC (Instrument Panel Cluster)	V			V																																											
General(CAN Bus)	ALL	ITM (Intrusion)	V			V																																											
General(CAN Bus)	ALL	LBSS (Left Blind Spot Sensor)	V			V																																											
General(CAN Bus)	ALL	LRSM (Light Rain Sensor Module)	V			V																																											
General(CAN Bus)	ALL	MSMD (Memory Seet Module)	V	V	V	V																																											
General(CAN Bus)	ALL	OCM (Occupant Classification Module)	V			V																																											
General(CAN Bus)	ALL	ORC (Occupant Restraint Control)	V	V		V																																											
General(CAN Bus)	ALL	PDM (Passenger Door Module)	V	V	V	V																																											
General(CAN Bus)	ALL	PLM (Power Liftgate Module)	V			V																																											
General(CAN Bus)	ALL	PTS (Park Assist Module)	V			V																																											
General(CAN Bus)	ALL	RADIO (Radio)	V	V		V																																											
General(CAN Bus)	ALL	RBSS (Right Blind Spot Sensor)	V			V																																											
General(CAN Bus)	ALL	RFH (Radio Frequency Hub)	V			V																																											
General(CAN Bus)	ALL	SAS (Steering Angle Sensor)	V	V	V	V																																											
General(CAN Bus)	ALL	SCM (Steering Column Module)	V			V																																											
General(CAN Bus)	ALL	SDAR (Satellite Radio)	V			V																																											
General(CAN Bus)	ALL	SUNR (Sunroof Module)	V			V																																											
General(CAN Bus)	ALL	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V					
General(CAN Bus)	ALL	TGW (Telematics Gateway)	V			V																																											
General(CAN Bus)	ALL	TPM (Tire Pressure Monitor)	V			V																																											

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
General(CAN Bus)	ALL	VES3 (Vidio Entertainment System 3)	V			V																																										
General(CAN Bus)	ALL	WCM(Wireless Control Modules)	V	V	V	V																																										
CHEROKEE	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHEROKEE	2016	ABS (Anti Lock Brake System)	V			V																																										
CHEROKEE	2016	ACC (Adaptive Cruise Control)	V			V																																										
CHEROKEE	2016	AMP (Audio)	V			V																																										
CHEROKEE	2016	BCM (Body Control Module)	V			V																																										
CHEROKEE	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
CHEROKEE	2016	CGW (Central Gateway)	V			V																																										
CHEROKEE	2016	DDM (Drivers Door Module)	V			V																																										
CHEROKEE	2016	DTCM (Drive Train Control Module)	V			V																																										
CHEROKEE	2016	EDM (Electronic Damper Module)	V			V																																										
CHEROKEE	2016	EPB (Electrical Parking Brake)	V	V		V																																										
CHEROKEE	2016	EPS (Electric Power Steering)	V			V																																										
CHEROKEE	2016	ESM (Electronic Shifter Module)	V			V																																										
CHEROKEE	2016	FFCM (Front Facing Camera Module)	V	V	V	V																																										
CHEROKEE	2016	HVAC (Heat Vent A/C)	V			V																																										
CHEROKEE	2016	ICS (Integrated Center Stack)	V			V																																										
CHEROKEE	2016	IPC (Instrument Panel Cluster)	V			V																																										
CHEROKEE	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
CHEROKEE	2016	MSMD (Memory Seet Module)	V			V																																										
CHEROKEE	2016	OCM (Occupant Classification Module)	V			V																																										
CHEROKEE	2016	ORC (Occupant Restraint Control)	V			V																																										
CHEROKEE	2016	PDM (Passenger Door Module)	V			V																																										
CHEROKEE	2016	PLM (Power Liftgate Module)	V			V																																										
CHEROKEE	2016	RADIO (Radio)	V			V																																										
CHEROKEE	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
CHEROKEE	2016	RFH (Radio Frequency Hub)	V			V																																										
CHEROKEE	2016	SCM (Steering Column Module)	V			V																																										
CHEROKEE	2016	TCM (Transmission Control Module)	V			V																																										
CHEROKEE	2016	WCM(Wireless Control Modules)	V			V																																										
CHEROKEE	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
CHEROKEE	2015	ABS (Anti Lock Brake System)	V			V																																										
CHEROKEE	2015	ACC (Adaptive Cruise Control)	V			V																																										
CHEROKEE	2015	AMP (Audio)	V			V																																										
CHEROKEE	2015	BCM (Body Control Module)	V			V																																										
CHEROKEE	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
CHEROKEE	2015	CGW (Central Gateway)	V			V																																										
CHEROKEE	2015	DDM (Drivers Door Module)	V			V																																										
CHEROKEE	2015	DTCM (Drive Train Control Module)	V			V																																										
CHEROKEE	2015	EDM (Electronic Damper Module)	V			V																																										
CHEROKEE	2015	EPB (Electrical Parking Brake)	V	V		V																																										
CHEROKEE	2015	EPS (Electric Power Steering)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CHEROKEE	2015	ESM (Electronic Shifter Module)	V			V																																										
CHEROKEE	2015	FFCM (Front Facing Camera Module)	V	V	V	V																																										
CHEROKEE	2015	HVAC (Heat Vent A/C)	V			V																																										
CHEROKEE	2015	ICS (Integrated Center Stack)	V			V																																										
CHEROKEE	2015	IPC (Instrument Panel Cluster)	V			V																																										
CHEROKEE	2015	LBSS (Left Blind Spot Sensor)	V			V																																										
CHEROKEE	2015	MSMD (Memory Seet Module)	V			V																																										
CHEROKEE	2015	OCM (Occupant Classification Module)	V			V																																										
CHEROKEE	2015	ORC (Occupant Restraint Control)	V			V																																										
CHEROKEE	2015	PDM (Passenger Door Module)	V			V																																										
CHEROKEE	2015	PLM (Power Liftgate Module)	V			V																																										
CHEROKEE	2015	RADIO (Radio)	V			V																																										
CHEROKEE	2015	RBSS (Right Blind Spot Sensor)	V			V																																										
CHEROKEE	2015	RFH (Radio Frequency Hub)	V			V																																										
CHEROKEE	2015	SCM (Steering Column Module)	V			V																																										
CHEROKEE	2015	TCM (Transmission Control Module)	V			V																																										
CHEROKEE	2015	WCM(Wireless Control Modules)	V			V																																										
CHEROKEE	2014	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V											
CHEROKEE	2014	ABS (Anti Lock Brake System)	V			V																																										
CHEROKEE	2014	ACC (Adaptive Cruise Control)	V			V																																										
CHEROKEE	2014	AMP (Audio)	V			V																																										
CHEROKEE	2014	BCM (Body Control Module)	V			V																																										
CHEROKEE	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
CHEROKEE	2014	CGW (Central Gateway)	V			V																																										
CHEROKEE	2014	DDM (Drivers Door Module)	V			V																																										
CHEROKEE	2014	DTCM (Drive Train Control Module)	V			V																																										
CHEROKEE	2014	EDM (Electronic Damper Module)	V			V																																										
CHEROKEE	2014	EPB (Electrical Parking Brake)	V	V		V																																										
CHEROKEE	2014	EPS (Electric Power Steering)	V			V																																										
CHEROKEE	2014	ESM (Electronic Shifter Module)	V			V																																										
CHEROKEE	2014	FFCM (Front Facing Camera Module)	V	V	V	V																																										
CHEROKEE	2014	HVAC (Heat Vent A/C)	V			V																																										
CHEROKEE	2014	ICS (Integrated Center Stack)	V			V																																										
CHEROKEE	2014	IPC (Instrument Panel Cluster)	V			V																																										
CHEROKEE	2014	LBSS (Left Blind Spot Sensor)	V			V																																										
CHEROKEE	2014	MSMD (Memory Seet Module)	V			V																																										
CHEROKEE	2014	OCM (Occupant Classification Module)	V			V																																										
CHEROKEE	2014	ORC (Occupant Restraint Control)	V			V																																										
CHEROKEE	2014	PDM (Passenger Door Module)	V			V																																										
CHEROKEE	2014	PLM (Power Liftgate Module)	V			V																																										
CHEROKEE	2014	RADIO (Radio)	V			V																																										
CHEROKEE	2014	RBSS (Right Blind Spot Sensor)	V			V																																										
CHEROKEE	2014	RFH (Radio Frequency Hub)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
CHEROKEE	2014	SCM (Steering Column Module)	V			V																																										
CHEROKEE	2014	TCM (Transmission Control Module)	V			V																																										
CHEROKEE	2014	WCM(Wireless Control Modules)	V			V																																										
GRAND CHEROKEE	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CHEROKEE	2016	ABS (Anti Lock Brake System)	V			V																																										
GRAND CHEROKEE	2016	ACC (Adaptive Cruise Control)	V			V																																										
GRAND CHEROKEE	2016	ADCM (Adaptive Damper Control Module)	V			V																																										
GRAND CHEROKEE	2016	AFLS (Adaptive Front Light System)	V			V																																										
GRAND CHEROKEE	2016	AMP (Audio)	V			V																																										
GRAND CHEROKEE	2016	BCM (Body Control Module)	V			V																																										
GRAND CHEROKEE	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
GRAND CHEROKEE	2016	CGW (Central Gateway)	V			V																																										
GRAND CHEROKEE	2016	DDM (Drivers Door Module)	V			V																																										
GRAND CHEROKEE	2016	DTCM (Drive Train Control Module)	V			V																																										
GRAND CHEROKEE	2016	EDM (Electronic Damper Module)	V			V																																										
GRAND CHEROKEE	2016	EPS (Electric Power Steering)	V			V																																										
GRAND CHEROKEE	2016	ESM (Electronic Shifter Module)	V			V																																										
GRAND CHEROKEE	2016	FFCM (Front Facing Camera Module)	V	V	V	V																																										
GRAND CHEROKEE	2016	HSM (Heated Seat Module)	V			V																																										
GRAND CHEROKEE	2016	HVAC (Heat Vent A/C)	V			V																																										
GRAND CHEROKEE	2016	ICS (Integrated Center Stack)	V			V																																										
GRAND CHEROKEE	2016	IPC (Instrument Panel Cluster)	V			V																																										
GRAND CHEROKEE	2016	ITM (Intrusion)	V			V																																										
GRAND CHEROKEE	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
GRAND CHEROKEE	2016	MSMD (Memory Seet Module)	V			V																																										
GRAND CHEROKEE	2016	ORC (Occupant Restraint Control)	V			V																																										
GRAND CHEROKEE	2016	PDM (Passenger Door Module)	V			V																																										
GRAND CHEROKEE	2016	PLM (Power Liftgate Module)	V			V																																										
GRAND CHEROKEE	2016	PTS (Park Assist Module)	V			V																																										
GRAND CHEROKEE	2016	RADIO (Radio)	V			V																																										
GRAND CHEROKEE	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
GRAND CHEROKEE	2016	RFH (Radio Frequency Hub)	V			V																																										
GRAND CHEROKEE	2016	SCM (Steering Column Module)	V			V																																										
GRAND CHEROKEE	2016	TCM (Transmission Control Module)	V			V																																										
GRAND CHEROKEE	2016	WCM(Wireless Control Modules)	V			V																																										
GRAND CHEROKEE	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CHEROKEE	2015	ABS (Anti Lock Brake System)	V			V																																										
GRAND CHEROKEE	2015	ACC (Adaptive Cruise Control)	V			V																																										
GRAND CHEROKEE	2015	ADCM (Adaptive Damper Control Module)	V			V																																										
GRAND CHEROKEE	2015	AFLS (Adaptive Front Light System)	V			V																																										
GRAND CHEROKEE	2015	AMP (Audio)	V			V																																										
GRAND CHEROKEE	2015	BCM (Body Control Module)	V			V																																										
GRAND CHEROKEE	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND CHEROKEE	2015	CGW (Central Gateway)	V			V																																										
GRAND CHEROKEE	2015	DDM (Drivers Door Module)	V			V																																										
GRAND CHEROKEE	2015	DTCM (Drive Train Control Module)	V			V																																										
GRAND CHEROKEE	2015	EDM (Electronic Damper Module)	V			V																																										
GRAND CHEROKEE	2015	EPS (Electric Power Steering)	V			V																																										
GRAND CHEROKEE	2015	ESM (Electronic Shifter Module)	V			V																																										
GRAND CHEROKEE	2015	FFCM (Front Facing Camera Module)	V	V	V	V																																										
GRAND CHEROKEE	2015	HSM (Heated Seat Module)	V			V																																										
GRAND CHEROKEE	2015	HVAC (Heat Vent A/C)	V			V																																										
GRAND CHEROKEE	2015	ICS (Integrated Center Stack)	V			V																																										
GRAND CHEROKEE	2015	IPC (Instrument Panel Cluster)	V			V																																										
GRAND CHEROKEE	2015	ITM (Intrusion)	V			V																																										
GRAND CHEROKEE	2015	LBSS (Left Blind Spot Sensor)	V			V																																										
GRAND CHEROKEE	2015	MSMD (Memory Seet Module)	V			V																																										
GRAND CHEROKEE	2015	ORC (Occupant Restraint Control)	V			V																																										
GRAND CHEROKEE	2015	PDM (Passenger Door Module)	V			V																																										
GRAND CHEROKEE	2015	PLM (Power Liftgate Module)	V			V																																										
GRAND CHEROKEE	2015	PTS (Park Assist Module)	V			V																																										
GRAND CHEROKEE	2015	RADIO (Radio)	V			V																																										
GRAND CHEROKEE	2015	RBSS (Right Blind Spot Sensor)	V			V																																										
GRAND CHEROKEE	2015	RFH (Radio Frequency Hub)	V			V																																										
GRAND CHEROKEE	2015	SCM (Steering Column Module)	V			V																																										
GRAND CHEROKEE	2015	TCM (Transmission Control Module)	V			V																																										
GRAND CHEROKEE	2015	WCM(Wireless Control Modules)	V			V																																										
GRAND CHEROKEE	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
GRAND CHEROKEE	2014	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CHEROKEE	2014	ACC (Adaptive Cruise Control)	V			V																																										
GRAND CHEROKEE	2014	AMP (Audio)	V	V		V																																										
GRAND CHEROKEE	2014	DDM (Drivers Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2014	DTCM (Drive Train Control Module)	V			V																																										
GRAND CHEROKEE	2014	ESM (Electronic Shifter Module)	V			V																																										
GRAND CHEROKEE	2014	HSM (Heated Seat Module)	V			V																																										
GRAND CHEROKEE	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CHEROKEE	2014	ITM (Intrusion)	V			V																																										
GRAND CHEROKEE	2014	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CHEROKEE	2014	PDM (Passenger Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2014	PLM (Power Liftgate Module)	V			V																																										
GRAND CHEROKEE	2014	PTS (Park Assist Module)	V			V																																										
GRAND CHEROKEE	2014	RADIO (Radio)	V	V		V																																										
GRAND CHEROKEE	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CHEROKEE	2014	TPM (Tire Pressure Monitor)	V			V																																										
GRAND CHEROKEE	2014	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CHEROKEE	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V											

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND CHEROKEE	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CHEROKEE	2013	ACC (Adaptive Cruise Control)	V			V																																										
GRAND CHEROKEE	2013	AHBM (Automatic High Beam)	V			V																																										
GRAND CHEROKEE	2013	AMP (Audio)	V	V		V																																										
GRAND CHEROKEE	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CHEROKEE	2013	DTCM (Drive Train Control Module)	V			V																																										
GRAND CHEROKEE	2013	ESM (Electronic Shifter Module)	V			V																																										
GRAND CHEROKEE	2013	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CHEROKEE	2013	HSM (Heated Seat Module)	V			V																																										
GRAND CHEROKEE	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CHEROKEE	2013	ITM (Intrusion)	V			V																																										
GRAND CHEROKEE	2013	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CHEROKEE	2013	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CHEROKEE	2013	PLM (Power Liftgate Module)	V			V																																										
GRAND CHEROKEE	2013	PTS (Park Assist Module)	V			V																																										
GRAND CHEROKEE	2013	RADIO (Radio)	V	V		V																																										
GRAND CHEROKEE	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CHEROKEE	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CHEROKEE	2013	CGW (Central Gateway)	V	V	V	V																																										
GRAND CHEROKEE	2013	TPM (Tire Pressure Monitor)	V			V																																										
GRAND CHEROKEE	2013	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CHEROKEE	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CHEROKEE	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CHEROKEE	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CHEROKEE	2012	ACC (Adaptive Cruise Control)	V			V																																										
GRAND CHEROKEE	2012	AHBM (Automatic High Beam)	V			V																																										
GRAND CHEROKEE	2012	AMP (Audio)	V	V		V																																										
GRAND CHEROKEE	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CHEROKEE	2012	DTCM (Drive Train Control Module)	V			V																																										
GRAND CHEROKEE	2012	ESM (Electronic Shifter Module)	V			V																																										
GRAND CHEROKEE	2012	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CHEROKEE	2012	HSM (Heated Seat Module)	V			V																																										
GRAND CHEROKEE	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CHEROKEE	2012	ITM (Intrusion)	V			V																																										
GRAND CHEROKEE	2012	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CHEROKEE	2012	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CHEROKEE	2012	PLM (Power Liftgate Module)	V			V																																										
GRAND CHEROKEE	2012	PTS (Park Assist Module)	V			V																																										
GRAND CHEROKEE	2012	RADIO (Radio)	V	V		V																																										
GRAND CHEROKEE	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CHEROKEE	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CHEROKEE	2012	CGW (Central Gateway)	V	V	V	V																																										
GRAND CHEROKEE	2012	TPM (Tire Pressure Monitor)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND CHEROKEE	2012	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CHEROKEE	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CHEROKEE	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CHEROKEE	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CHEROKEE	2011	ACC (Adaptive Cruise Control)	V			V																																										
GRAND CHEROKEE	2011	AHBM (Automatic High Beam)	V			V																																										
GRAND CHEROKEE	2011	AMP (Audio)	V	V		V																																										
GRAND CHEROKEE	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CHEROKEE	2011	DTCM (Drive Train Control Module)	V			V																																										
GRAND CHEROKEE	2011	ESM (Electronic Shifter Module)	V			V																																										
GRAND CHEROKEE	2011	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CHEROKEE	2011	HSM (Heated Seat Module)	V			V																																										
GRAND CHEROKEE	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CHEROKEE	2011	ITM (Intrusion)	V			V																																										
GRAND CHEROKEE	2011	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CHEROKEE	2011	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CHEROKEE	2011	PLM (Power Liftgate Module)	V			V																																										
GRAND CHEROKEE	2011	PTS (Park Assist Module)	V			V																																										
GRAND CHEROKEE	2011	RADIO (Radio)	V	V		V																																										
GRAND CHEROKEE	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CHEROKEE	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CHEROKEE	2011	CGW (Central Gateway)	V	V	V	V																																										
GRAND CHEROKEE	2011	TPM (Tire Pressure Monitor)	V			V																																										
GRAND CHEROKEE	2011	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CHEROKEE	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CHEROKEE	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CHEROKEE	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CHEROKEE	2010	AHBM (Automatic High Beam)	V			V																																										
GRAND CHEROKEE	2010	AMP (Audio)	V	V		V																																										
GRAND CHEROKEE	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CHEROKEE	2010	DDM (Drivers Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2010	EOM (Electric Overhead Module)	V	V	V	V																																										
GRAND CHEROKEE	2010	ESM (Electronic Shifter Module)	V			V																																										
GRAND CHEROKEE	2010	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CHEROKEE	2010	HSM (Heated Seat Module)	V			V																																										
GRAND CHEROKEE	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CHEROKEE	2010	ITM (Intrusion)	V			V																																										
GRAND CHEROKEE	2010	LRSM (Light Rain Sensor Module)	V			V																																										
GRAND CHEROKEE	2010	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CHEROKEE	2010	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CHEROKEE	2010	PDM (Passenger Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2010	PTS (Park Assist Module)	V			V																																										
GRAND CHEROKEE	2010	RADIO (Radio)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND CHEROKEE	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CHEROKEE	2010	SUNR (Sunroof Module)	V			V																																										
GRAND CHEROKEE	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CHEROKEE	2010	CGW (Central Gateway)	V	V	V	V																																										
GRAND CHEROKEE	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CHEROKEE	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CHEROKEE	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CHEROKEE	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CHEROKEE	2009	AHBM (Automatic High Beam)	V			V																																										
GRAND CHEROKEE	2009	AMP (Audio)	V	V		V																																										
GRAND CHEROKEE	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CHEROKEE	2009	DDM (Drivers Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2009	EOM (Electric Overhead Module)	V	V	V	V																																										
GRAND CHEROKEE	2009	ESM (Electronic Shifter Module)	V			V																																										
GRAND CHEROKEE	2009	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CHEROKEE	2009	HSM (Heated Seat Module)	V			V																																										
GRAND CHEROKEE	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CHEROKEE	2009	ITM (Intrusion)	V			V																																										
GRAND CHEROKEE	2009	LRSM (Light Rain Sensor Module)	V			V																																										
GRAND CHEROKEE	2009	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CHEROKEE	2009	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CHEROKEE	2009	PDM (Passenger Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2009	PTS (Park Assist Module)	V			V																																										
GRAND CHEROKEE	2009	RADIO (Radio)	V	V		V																																										
GRAND CHEROKEE	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CHEROKEE	2009	SUNR (Sunroof Module)	V			V																																										
GRAND CHEROKEE	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CHEROKEE	2009	CGW (Central Gateway)	V	V	V	V																																										
GRAND CHEROKEE	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CHEROKEE	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CHEROKEE	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CHEROKEE	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CHEROKEE	2008	AHBM (Automatic High Beam)	V			V																																										
GRAND CHEROKEE	2008	AMP (Audio)	V	V		V																																										
GRAND CHEROKEE	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CHEROKEE	2008	DDM (Drivers Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2008	EOM (Electric Overhead Module)	V	V	V	V																																										
GRAND CHEROKEE	2008	ESM (Electronic Shifter Module)	V			V																																										
GRAND CHEROKEE	2008	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CHEROKEE	2008	HSM (Heated Seat Module)	V			V																																										
GRAND CHEROKEE	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CHEROKEE	2008	ITM (Intrusion)	V			V																																										
GRAND CHEROKEE	2008	LRSM (Light Rain Sensor Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND CHEROKEE	2008	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CHEROKEE	2008	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CHEROKEE	2008	PDM (Passenger Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2008	PTS (Park Assist Module)	V			V																																										
GRAND CHEROKEE	2008	RADIO (Radio)	V	V		V																																										
GRAND CHEROKEE	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
GRAND CHEROKEE	2008	SUNR (Sunroof Module)	V			V																																										
GRAND CHEROKEE	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CHEROKEE	2008	CGW (Central Gateway)	V	V	V	V																																										
GRAND CHEROKEE	2008	VES3 (Vidio Entertainment System 3)	V			V																																										
GRAND CHEROKEE	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CHEROKEE	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CHEROKEE	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CHEROKEE	2007	AHBM (Automatic High Beam)	V			V																																										
GRAND CHEROKEE	2007	AMP (Audio)	V	V		V																																										
GRAND CHEROKEE	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CHEROKEE	2007	DDM (Drivers Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2007	EOM (Electric Overhead Module)	V	V	V	V																																										
GRAND CHEROKEE	2007	ESM (Electronic Shifter Module)	V			V																																										
GRAND CHEROKEE	2007	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CHEROKEE	2007	HSM (Heated Seat Module)	V			V																																										
GRAND CHEROKEE	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CHEROKEE	2007	ITM (Intrusion)	V			V																																										
GRAND CHEROKEE	2007	LRSM (Light Rain Sensor Module)	V			V																																										
GRAND CHEROKEE	2007	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CHEROKEE	2007	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CHEROKEE	2007	PDM (Passenger Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2007	PTS (Park Assist Module)	V			V																																										
GRAND CHEROKEE	2007	RADIO (Radio)	V	V		V																																										
GRAND CHEROKEE	2007	SCM (Steering Column Module)	V			V																																										
GRAND CHEROKEE	2007	SDAR (Satellite Radio)	V			V																																										
GRAND CHEROKEE	2007	SUNR (Sunroof Module)	V			V																																										
GRAND CHEROKEE	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CHEROKEE	2007	CGW (Central Gateway)	V	V	V	V																																										
GRAND CHEROKEE	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CHEROKEE	2006	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CHEROKEE	2006	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CHEROKEE	2006	AHBM (Automatic High Beam)	V			V																																										
GRAND CHEROKEE	2006	AMP (Audio)	V	V		V																																										
GRAND CHEROKEE	2006	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CHEROKEE	2006	DDM (Drivers Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2006	EOM (Electric Overhead Module)	V	V	V	V																																										
GRAND CHEROKEE	2006	ESM (Electronic Shifter Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
GRAND CHEROKEE	2006	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CHEROKEE	2006	HSM (Heated Seat Module)	V			V																																										
GRAND CHEROKEE	2006	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CHEROKEE	2006	ITM (Intrusion)	V			V																																										
GRAND CHEROKEE	2006	LRSM (Light Rain Sensor Module)	V			V																																										
GRAND CHEROKEE	2006	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CHEROKEE	2006	OCM (Occupant Classification Module)	V			V																																										
GRAND CHEROKEE	2006	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CHEROKEE	2006	PDM (Passenger Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2006	PTS (Park Assist Module)	V			V																																										
GRAND CHEROKEE	2006	RADIO (Radio)	V	V		V																																										
GRAND CHEROKEE	2006	SCM (Steering Column Module)	V			V																																										
GRAND CHEROKEE	2006	SDAR (Satellite Radio)	V			V																																										
GRAND CHEROKEE	2006	SUNR (Sunroof Module)	V			V																																										
GRAND CHEROKEE	2006	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CHEROKEE	2006	CGW (Central Gateway)	V	V	V	V																																										
GRAND CHEROKEE	2006	WCM(Wireless Control Modules)	V	V	V	V																																										
GRAND CHEROKEE	2005	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
GRAND CHEROKEE	2005	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
GRAND CHEROKEE	2005	AHBM (Automatic High Beam)	V			V																																										
GRAND CHEROKEE	2005	AMP (Audio)	V	V		V																																										
GRAND CHEROKEE	2005	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
GRAND CHEROKEE	2005	DDM (Drivers Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2005	EOM (Electric Overhead Module)	V	V	V	V																																										
GRAND CHEROKEE	2005	ESM (Electronic Shifter Module)	V			V																																										
GRAND CHEROKEE	2005	HFM (Hands Free Module)	V	V	V	V																																										
GRAND CHEROKEE	2005	HSM (Heated Seat Module)	V			V																																										
GRAND CHEROKEE	2005	HVAC (Heat Vent A/C)	V	V	V	V																																										
GRAND CHEROKEE	2005	ITM (Intrusion)	V			V																																										
GRAND CHEROKEE	2005	LRSM (Light Rain Sensor Module)	V			V																																										
GRAND CHEROKEE	2005	MSMD (Memory Seet Module)	V	V	V	V																																										
GRAND CHEROKEE	2005	OCM (Occupant Classification Module)	V			V																																										
GRAND CHEROKEE	2005	ORC (Occupant Restraint Control)	V	V		V																																										
GRAND CHEROKEE	2005	PDM (Passenger Door Module)	V	V	V	V																																										
GRAND CHEROKEE	2005	PTS (Park Assist Module)	V			V																																										
GRAND CHEROKEE	2005	RADIO (Radio)	V	V		V																																										
GRAND CHEROKEE	2005	SCM (Steering Column Module)	V			V																																										
GRAND CHEROKEE	2005	SDAR (Satellite Radio)	V			V																																										
GRAND CHEROKEE	2005	SUNR (Sunroof Module)	V			V																																										
GRAND CHEROKEE	2005	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
GRAND CHEROKEE	2005	CGW (Central Gateway)	V	V	V	V																																										
GRAND CHEROKEE	2005	WCM(Wireless Control Modules)	V	V	V	V																																										
LIBERTY	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
LIBERTY	2015	ABS (Anti Lock Brake System)	V			V																																										
LIBERTY	2015	AMP (Audio)	V			V																																										
LIBERTY	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
LIBERTY	2015	CGW (Central Gateway)	V			V																																										
LIBERTY	2015	ESM (Electronic Shifter Module)	V			V																																										
LIBERTY	2015	FDCM/AWD (Final Drive Control / All Wheel Drive)	V			V																																										
LIBERTY	2015	HFM (Hands Free Module)	V			V																																										
LIBERTY	2015	HVAC (Heat Vent A/C)	V			V																																										
LIBERTY	2015	ITM (Intrusion)	V			V																																										
LIBERTY	2015	MSMD (Memory Seet Module)	V			V																																										
LIBERTY	2015	OCM (Occupant Classification Module)	V			V																																										
LIBERTY	2015	ORC (Occupant Restraint Control)	V			V																																										
LIBERTY	2015	PTS (Park Assist Module)	V			V																																										
LIBERTY	2015	RADIO (Radio)	V			V																																										
LIBERTY	2015	RFH (Radio Frequency Hub)	V			V																																										
LIBERTY	2015	SAS (Steering Angle Sensor)	V			V																																										
LIBERTY	2015	SUNR (Sunroof Module)	V			V																																										
LIBERTY	2015	TCM (Transmission Control Module)	V			V																																										
LIBERTY	2015	WCM(Wireless Control Modules)	V			V																																										
LIBERTY	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
LIBERTY	2014	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
LIBERTY	2014	AMP (Audio)	V	V		V																																										
LIBERTY	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
LIBERTY	2014	ESM (Electronic Shifter Module)	V			V																																										
LIBERTY	2014	HFM (Hands Free Module)	V	V	V	V																																										
LIBERTY	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
LIBERTY	2014	ITM (Intrusion)	V			V																																										
LIBERTY	2014	MSMD (Memory Seet Module)	V	V	V	V																																										
LIBERTY	2014	OCM (Occupant Classification Module)	V			V																																										
LIBERTY	2014	ORC (Occupant Restraint Control)	V	V		V																																										
LIBERTY	2014	PTS (Park Assist Module)	V			V																																										
LIBERTY	2014	RADIO (Radio)	V	V		V																																										
LIBERTY	2014	SAS (Steering Angle Sensor)	V	V	V	V																																										
LIBERTY	2014	SUNR (Sunroof Module)	V			V																																										
LIBERTY	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
LIBERTY	2014	CGW (Central Gateway)	V	V	V	V																																										
LIBERTY	2014	WCM(Wireless Control Modules)	V	V	V	V																																										
LIBERTY	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
LIBERTY	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
LIBERTY	2013	AMP (Audio)	V	V		V																																										
LIBERTY	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
LIBERTY	2013	ESM (Electronic Shifter Module)	V			V																																										
LIBERTY	2013	HFM (Hands Free Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
LIBERTY	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
LIBERTY	2013	ITM (Intrusion)	V			V																																										
LIBERTY	2013	MSMD (Memory Seet Module)	V	V	V	V																																										
LIBERTY	2013	OCM (Occupant Classification Module)	V			V																																										
LIBERTY	2013	ORC (Occupant Restraint Control)	V	V		V																																										
LIBERTY	2013	PTS (Park Assist Module)	V			V																																										
LIBERTY	2013	RADIO (Radio)	V	V		V																																										
LIBERTY	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
LIBERTY	2013	SUNR (Sunroof Module)	V			V																																										
LIBERTY	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
LIBERTY	2013	CGW (Central Gateway)	V	V	V	V																																										
LIBERTY	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
LIBERTY	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
LIBERTY	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
LIBERTY	2012	AMP (Audio)	V	V		V																																										
LIBERTY	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
LIBERTY	2012	ESM (Electronic Shifter Module)	V			V																																										
LIBERTY	2012	HFM (Hands Free Module)	V	V	V	V																																										
LIBERTY	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
LIBERTY	2012	ITM (Intrusion)	V			V																																										
LIBERTY	2012	MSMD (Memory Seet Module)	V	V	V	V																																										
LIBERTY	2012	OCM (Occupant Classification Module)	V			V																																										
LIBERTY	2012	ORC (Occupant Restraint Control)	V	V		V																																										
LIBERTY	2012	PTS (Park Assist Module)	V			V																																										
LIBERTY	2012	RADIO (Radio)	V	V		V																																										
LIBERTY	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
LIBERTY	2012	SUNR (Sunroof Module)	V			V																																										
LIBERTY	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
LIBERTY	2012	CGW (Central Gateway)	V	V	V	V																																										
LIBERTY	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
LIBERTY	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
LIBERTY	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
LIBERTY	2011	AMP (Audio)	V	V		V																																										
LIBERTY	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
LIBERTY	2011	ESM (Electronic Shifter Module)	V			V																																										
LIBERTY	2011	HFM (Hands Free Module)	V	V	V	V																																										
LIBERTY	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
LIBERTY	2011	ITM (Intrusion)	V			V																																										
LIBERTY	2011	MSMD (Memory Seet Module)	V	V	V	V																																										
LIBERTY	2011	OCM (Occupant Classification Module)	V			V																																										
LIBERTY	2011	ORC (Occupant Restraint Control)	V	V		V																																										
LIBERTY	2011	PTS (Park Assist Module)	V			V																																										
LIBERTY	2011	RADIO (Radio)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
LIBERTY	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
LIBERTY	2011	SUNR (Sunroof Module)	V			V																																										
LIBERTY	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
LIBERTY	2011	CGW (Central Gateway)	V	V	V	V																																										
LIBERTY	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
LIBERTY	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
LIBERTY	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
LIBERTY	2010	AMP (Audio)	V	V		V																																										
LIBERTY	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
LIBERTY	2010	ESM (Electronic Shifter Module)	V			V																																										
LIBERTY	2010	HFM (Hands Free Module)	V	V	V	V																																										
LIBERTY	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
LIBERTY	2010	ITM (Intrusion)	V			V																																										
LIBERTY	2010	MSMD (Memory Seet Module)	V	V	V	V																																										
LIBERTY	2010	OCM (Occupant Classification Module)	V			V																																										
LIBERTY	2010	ORC (Occupant Restraint Control)	V	V		V																																										
LIBERTY	2010	PTS (Park Assist Module)	V			V																																										
LIBERTY	2010	RADIO (Radio)	V	V		V																																										
LIBERTY	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
LIBERTY	2010	SUNR (Sunroof Module)	V			V																																										
LIBERTY	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
LIBERTY	2010	CGW (Central Gateway)	V	V	V	V																																										
LIBERTY	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
LIBERTY	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
LIBERTY	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
LIBERTY	2009	AMP (Audio)	V	V		V																																										
LIBERTY	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
LIBERTY	2009	ESM (Electronic Shifter Module)	V			V																																										
LIBERTY	2009	HFM (Hands Free Module)	V	V	V	V																																										
LIBERTY	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
LIBERTY	2009	ITM (Intrusion)	V			V																																										
LIBERTY	2009	MSMD (Memory Seet Module)	V	V	V	V																																										
LIBERTY	2009	OCM (Occupant Classification Module)	V			V																																										
LIBERTY	2009	ORC (Occupant Restraint Control)	V	V		V																																										
LIBERTY	2009	PTS (Park Assist Module)	V			V																																										
LIBERTY	2009	RADIO (Radio)	V	V		V																																										
LIBERTY	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
LIBERTY	2009	SUNR (Sunroof Module)	V			V																																										
LIBERTY	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
LIBERTY	2009	CGW (Central Gateway)	V	V	V	V																																										
LIBERTY	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
LIBERTY	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
LIBERTY	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
LIBERTY	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
LIBERTY	2008	AMP (Audio)	V	V		V																																										
LIBERTY	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
LIBERTY	2008	ESM (Electronic Shifter Module)	V			V																																										
LIBERTY	2008	HFM (Hands Free Module)	V	V	V	V																																										
LIBERTY	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
LIBERTY	2008	ITM (Intrusion)	V			V																																										
LIBERTY	2008	MSMD (Memory Seet Module)	V	V	V	V																																										
LIBERTY	2008	OCM (Occupant Classification Module)	V			V																																										
LIBERTY	2008	ORC (Occupant Restraint Control)	V	V		V																																										
LIBERTY	2008	PTS (Park Assist Module)	V			V																																										
LIBERTY	2008	RADIO (Radio)	V	V		V																																										
LIBERTY	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
LIBERTY	2008	SUNR (Sunroof Module)	V			V																																										
LIBERTY	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
LIBERTY	2008	CGW (Central Gateway)	V	V	V	V																																										
LIBERTY	2008	VES3 (Vidio Entertainment System 3)	V			V																																										
LIBERTY	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
LIBERTY	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
LIBERTY	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
LIBERTY	2007	SAS (Steering Angle Sensor)	V	V	V	V																																										
LIBERTY	2006	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
LIBERTY	2006	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
LIBERTY	2006	SAS (Steering Angle Sensor)	V	V	V	V																																										
LIBERTY	2006	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAIDER	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAIDER	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAIDER	2010	AMP (Audio)	V	V		V																																										
RAIDER	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAIDER	2010	EOM (Electric Overhead Module)	V	V	V	V																																										
RAIDER	2010	HFM (Hands Free Module)	V	V	V	V																																										
RAIDER	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAIDER	2010	ORC (Occupant Restraint Control)	V	V		V																																										
RAIDER	2010	RADIO (Radio)	V	V		V																																										
RAIDER	2010	CGW (Central Gateway)	V	V	V	V																																										
RAIDER	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
RAIDER	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAIDER	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAIDER	2009	AMP (Audio)	V	V		V																																										
RAIDER	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAIDER	2009	EOM (Electric Overhead Module)	V	V	V	V																																										
RAIDER	2009	HFM (Hands Free Module)	V	V	V	V																																										
RAIDER	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RAIDER	2009	ORC (Occupant Restraint Control)	V	V		V																																										
RAIDER	2009	RADIO (Radio)	V	V		V																																										
RAIDER	2009	CGW (Central Gateway)	V	V	V	V																																										
RAIDER	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
RAIDER	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAIDER	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAIDER	2008	AMP (Audio)	V	V		V																																										
RAIDER	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAIDER	2008	EOM (Electric Overhead Module)	V	V	V	V																																										
RAIDER	2008	HFM (Hands Free Module)	V	V	V	V																																										
RAIDER	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAIDER	2008	ORC (Occupant Restraint Control)	V	V		V																																										
RAIDER	2008	RADIO (Radio)	V	V		V																																										
RAIDER	2008	CGW (Central Gateway)	V	V	V	V																																										
RAIDER	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
RAIDER	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAIDER	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAIDER	2007	AMP (Audio)	V	V		V																																										
RAIDER	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAIDER	2007	EOM (Electric Overhead Module)	V	V	V	V																																										
RAIDER	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAIDER	2007	OCM (Occupant Classification Module)	V			V																																										
RAIDER	2007	ORC (Occupant Restraint Control)	V	V		V																																										
RAIDER	2007	RADIO (Radio)	V	V		V																																										
RAIDER	2007	SDAR (Satellite Radio)	V			V																																										
RAIDER	2007	CGW (Central Gateway)	V	V	V	V																																										
RAIDER	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
RAIDER	2006	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RAIDER	2006	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
RAIDER	2006	AMP (Audio)	V	V		V																																										
RAIDER	2006	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
RAIDER	2006	EOM (Electric Overhead Module)	V	V	V	V																																										
RAIDER	2006	HFM (Hands Free Module)	V	V	V	V																																										
RAIDER	2006	HVAC (Heat Vent A/C)	V	V	V	V																																										
RAIDER	2006	OCM (Occupant Classification Module)	V			V																																										
RAIDER	2006	ORC (Occupant Restraint Control)	V	V		V																																										
RAIDER	2006	RADIO (Radio)	V	V		V																																										
RAIDER	2006	SDAR (Satellite Radio)	V			V																																										
RAIDER	2006	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
RAIDER	2006	CGW (Central Gateway)	V	V	V	V																																										
RAIDER	2006	WCM(Wireless Control Modules)	V	V	V	V																																										
COMMANDER	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMMANDER	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
COMMANDER	2010	AHBM (Automatic High Beam)	V			V																																										
COMMANDER	2010	AMP (Audio)	V	V		V																																										
COMMANDER	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMMANDER	2010	DDM (Drivers Door Module)	V	V	V	V																																										
COMMANDER	2010	ESM (Electronic Shifter Module)	V			V																																										
COMMANDER	2010	HFM (Hands Free Module)	V	V	V	V																																										
COMMANDER	2010	HSM (Heated Seat Module)	V			V																																										
COMMANDER	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
COMMANDER	2010	ITM (Intrusion)	V			V																																										
COMMANDER	2010	LRSM (Light Rain Sensor Module)	V			V																																										
COMMANDER	2010	MSMD (Memory Seet Module)	V	V	V	V																																										
COMMANDER	2010	ORC (Occupant Restraint Control)	V	V		V																																										
COMMANDER	2010	PDM (Passenger Door Module)	V	V	V	V																																										
COMMANDER	2010	PLM (Power Liftgate Module)	V			V																																										
COMMANDER	2010	PTS (Park Assist Module)	V			V																																										
COMMANDER	2010	RADIO (Radio)	V	V		V																																										
COMMANDER	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
COMMANDER	2010	SUNR (Sunroof Module)	V			V																																										
COMMANDER	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
COMMANDER	2010	CGW (Central Gateway)	V	V	V	V																																										
COMMANDER	2010	VES3 (Vidio Entertainment System 3)	V			V																																										
COMMANDER	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
COMMANDER	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMMANDER	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
COMMANDER	2009	AHBM (Automatic High Beam)	V			V																																										
COMMANDER	2009	AMP (Audio)	V	V		V																																										
COMMANDER	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMMANDER	2009	DDM (Drivers Door Module)	V	V	V	V																																										
COMMANDER	2009	ESM (Electronic Shifter Module)	V			V																																										
COMMANDER	2009	HFM (Hands Free Module)	V	V	V	V																																										
COMMANDER	2009	HSM (Heated Seat Module)	V			V																																										
COMMANDER	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
COMMANDER	2009	ITM (Intrusion)	V			V																																										
COMMANDER	2009	LRSM (Light Rain Sensor Module)	V			V																																										
COMMANDER	2009	MSMD (Memory Seet Module)	V	V	V	V																																										
COMMANDER	2009	ORC (Occupant Restraint Control)	V	V		V																																										
COMMANDER	2009	PDM (Passenger Door Module)	V	V	V	V																																										
COMMANDER	2009	PLM (Power Liftgate Module)	V			V																																										
COMMANDER	2009	PTS (Park Assist Module)	V			V																																										
COMMANDER	2009	RADIO (Radio)	V	V		V																																										
COMMANDER	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
COMMANDER	2009	SUNR (Sunroof Module)	V			V																																										
COMMANDER	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
COMMANDER	2009	CGW (Central Gateway)	V	V	V	V																																										
COMMANDER	2009	VES3 (Vidio Entertainment System 3)	V			V																																										
COMMANDER	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
COMMANDER	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMMANDER	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
COMMANDER	2008	AHBM (Automatic High Beam)	V			V																																										
COMMANDER	2008	AMP (Audio)	V	V		V																																										
COMMANDER	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMMANDER	2008	DDM (Drivers Door Module)	V	V	V	V																																										
COMMANDER	2008	ESM (Electronic Shifter Module)	V			V																																										
COMMANDER	2008	HFM (Hands Free Module)	V	V	V	V																																										
COMMANDER	2008	HSM (Heated Seat Module)	V			V																																										
COMMANDER	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
COMMANDER	2008	ITM (Intrusion)	V			V																																										
COMMANDER	2008	LRSM (Light Rain Sensor Module)	V			V																																										
COMMANDER	2008	MSMD (Memory Seet Module)	V	V	V	V																																										
COMMANDER	2008	ORC (Occupant Restraint Control)	V	V		V																																										
COMMANDER	2008	PDM (Passenger Door Module)	V	V	V	V																																										
COMMANDER	2008	PLM (Power Liftgate Module)	V			V																																										
COMMANDER	2008	PTS (Park Assist Module)	V			V																																										
COMMANDER	2008	RADIO (Radio)	V	V		V																																										
COMMANDER	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
COMMANDER	2008	SUNR (Sunroof Module)	V			V																																										
COMMANDER	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
COMMANDER	2008	CGW (Central Gateway)	V	V	V	V																																										
COMMANDER	2008	VES3 (Vidio Entertainment System 3)	V			V																																										
COMMANDER	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
COMMANDER	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMMANDER	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
COMMANDER	2007	AHBM (Automatic High Beam)	V			V																																										
COMMANDER	2007	AMP (Audio)	V	V		V																																										
COMMANDER	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMMANDER	2007	DDM (Drivers Door Module)	V	V	V	V																																										
COMMANDER	2007	ESM (Electronic Shifter Module)	V			V																																										
COMMANDER	2007	HFM (Hands Free Module)	V	V	V	V																																										
COMMANDER	2007	HSM (Heated Seat Module)	V			V																																										
COMMANDER	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
COMMANDER	2007	ITM (Intrusion)	V			V																																										
COMMANDER	2007	LRSM (Light Rain Sensor Module)	V			V																																										
COMMANDER	2007	MSMD (Memory Seet Module)	V	V	V	V																																										
COMMANDER	2007	OCM (Occupant Classification Module)	V			V																																										
COMMANDER	2007	ORC (Occupant Restraint Control)	V	V		V																																										
COMMANDER	2007	PDM (Passenger Door Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
COMMANDER	2007	PTS (Park Assist Module)	V			V																																										
COMMANDER	2007	RADIO (Radio)	V	V		V																																										
COMMANDER	2007	SCM (Steering Column Module)	V			V																																										
COMMANDER	2007	SDAR (Satellite Radio)	V			V																																										
COMMANDER	2007	SUNR (Sunroof Module)	V			V																																										
COMMANDER	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
COMMANDER	2007	CGW (Central Gateway)	V	V	V	V																																										
COMMANDER	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
COMMANDER	2006	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMMANDER	2006	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
COMMANDER	2006	AHBM (Automatic High Beam)	V			V																																										
COMMANDER	2006	AMP (Audio)	V	V		V																																										
COMMANDER	2006	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMMANDER	2006	DDM (Drivers Door Module)	V	V	V	V																																										
COMMANDER	2006	ESM (Electronic Shifter Module)	V			V																																										
COMMANDER	2006	HFM (Hands Free Module)	V	V	V	V																																										
COMMANDER	2006	HSM (Heated Seat Module)	V			V																																										
COMMANDER	2006	HVAC (Heat Vent A/C)	V	V	V	V																																										
COMMANDER	2006	ITM (Intrusion)	V			V																																										
COMMANDER	2006	LRSM (Light Rain Sensor Module)	V			V																																										
COMMANDER	2006	MSMD (Memory Seet Module)	V	V	V	V																																										
COMMANDER	2006	OCM (Occupant Classification Module)	V			V																																										
COMMANDER	2006	ORC (Occupant Restraint Control)	V	V		V																																										
COMMANDER	2006	PDM (Passenger Door Module)	V	V	V	V																																										
COMMANDER	2006	PTS (Park Assist Module)	V			V																																										
COMMANDER	2006	RADIO (Radio)	V	V		V																																										
COMMANDER	2006	SCM (Steering Column Module)	V			V																																										
COMMANDER	2006	SDAR (Satellite Radio)	V			V																																										
COMMANDER	2006	SUNR (Sunroof Module)	V			V																																										
COMMANDER	2006	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
COMMANDER	2006	CGW (Central Gateway)	V	V	V	V																																										
COMMANDER	2006	WCM(Wireless Control Modules)	V	V	V	V																																										
WRANGLER	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
WRANGLER	2016	ABS (Anti Lock Brake System)	V			V																																										
WRANGLER	2016	AMP (Audio)	V			V																																										
WRANGLER	2016	BCM (Body Control Module)	V			V																																										
WRANGLER	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
WRANGLER	2016	CGW (Central Gateway)	V			V																																										
WRANGLER	2016	ESM (Electronic Shifter Module)	V			V																																										
WRANGLER	2016	HFM (Hands Free Module)	V			V																																										
WRANGLER	2016	HVAC (Heat Vent A/C)	V			V																																										
WRANGLER	2016	ITM (Intrusion)	V			V																																										
WRANGLER	2016	ORC (Occupant Restraint Control)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
WRANGLER	2016	RADIO (Radio)	V			V																																										
WRANGLER	2016	RFH (Radio Frequency Hub)	V			V																																										
WRANGLER	2016	SAS (Steering Angle Sensor)	V			V																																										
WRANGLER	2016	TCM (Transmission Control Module)	V			V																																										
WRANGLER	2016	TPM (Tire Pressure Monitor)	V			V																																										
WRANGLER	2016	WCM(Wireless Control Modules)	V			V																																										
WRANGLER	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
WRANGLER	2015	ABS (Anti Lock Brake System)	V			V																																										
WRANGLER	2015	AMP (Audio)	V			V																																										
WRANGLER	2015	BCM (Body Control Module)	V			V																																										
WRANGLER	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
WRANGLER	2015	CGW (Central Gateway)	V			V																																										
WRANGLER	2015	ESM (Electronic Shifter Module)	V			V																																										
WRANGLER	2015	HFM (Hands Free Module)	V			V																																										
WRANGLER	2015	HVAC (Heat Vent A/C)	V			V																																										
WRANGLER	2015	ITM (Intrusion)	V			V																																										
WRANGLER	2015	ORC (Occupant Restraint Control)	V			V																																										
WRANGLER	2015	RADIO (Radio)	V			V																																										
WRANGLER	2015	RFH (Radio Frequency Hub)	V			V																																										
WRANGLER	2015	SAS (Steering Angle Sensor)	V			V																																										
WRANGLER	2015	TCM (Transmission Control Module)	V			V																																										
WRANGLER	2015	TPM (Tire Pressure Monitor)	V			V																																										
WRANGLER	2015	WCM(Wireless Control Modules)	V			V																																										
WRANGLER	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
WRANGLER	2014	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
WRANGLER	2014	AMP (Audio)	V	V		V																																										
WRANGLER	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
WRANGLER	2014	ESM (Electronic Shifter Module)	V			V																																										
WRANGLER	2014	HFM (Hands Free Module)	V	V	V	V																																										
WRANGLER	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
WRANGLER	2014	ITM (Intrusion)	V			V																																										
WRANGLER	2014	ORC (Occupant Restraint Control)	V	V		V																																										
WRANGLER	2014	RADIO (Radio)	V	V		V																																										
WRANGLER	2014	SAS (Steering Angle Sensor)	V	V	V	V																																										
WRANGLER	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
WRANGLER	2014	CGW (Central Gateway)	V	V	V	V																																										
WRANGLER	2014	TPM (Tire Pressure Monitor)	V			V																																										
WRANGLER	2014	WCM(Wireless Control Modules)	V	V	V	V																																										
WRANGLER	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
WRANGLER	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
WRANGLER	2013	AMP (Audio)	V	V		V																																										
WRANGLER	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
WRANGLER	2013	ESM (Electronic Shifter Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
WRANGLER	2013	HFM (Hands Free Module)	V	V	V	V																																										
WRANGLER	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
WRANGLER	2013	ITM (Intrusion)	V			V																																										
WRANGLER	2013	ORC (Occupant Restraint Control)	V	V		V																																										
WRANGLER	2013	RADIO (Radio)	V	V		V																																										
WRANGLER	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
WRANGLER	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
WRANGLER	2013	CGW (Central Gateway)	V	V	V	V																																										
WRANGLER	2013	TPM (Tire Pressure Monitor)	V			V																																										
WRANGLER	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
WRANGLER	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
WRANGLER	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
WRANGLER	2012	AMP (Audio)	V	V		V																																										
WRANGLER	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
WRANGLER	2012	ESM (Electronic Shifter Module)	V			V																																										
WRANGLER	2012	HFM (Hands Free Module)	V	V	V	V																																										
WRANGLER	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
WRANGLER	2012	ITM (Intrusion)	V			V																																										
WRANGLER	2012	ORC (Occupant Restraint Control)	V	V		V																																										
WRANGLER	2012	RADIO (Radio)	V	V		V																																										
WRANGLER	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
WRANGLER	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
WRANGLER	2012	CGW (Central Gateway)	V	V	V	V																																										
WRANGLER	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
WRANGLER	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
WRANGLER	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
WRANGLER	2011	AMP (Audio)	V	V		V																																										
WRANGLER	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
WRANGLER	2011	ESM (Electronic Shifter Module)	V			V																																										
WRANGLER	2011	HFM (Hands Free Module)	V	V	V	V																																										
WRANGLER	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
WRANGLER	2011	ITM (Intrusion)	V			V																																										
WRANGLER	2011	ORC (Occupant Restraint Control)	V	V		V																																										
WRANGLER	2011	RADIO (Radio)	V	V		V																																										
WRANGLER	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
WRANGLER	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
WRANGLER	2011	CGW (Central Gateway)	V	V	V	V																																										
WRANGLER	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
WRANGLER	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
WRANGLER	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
WRANGLER	2010	AMP (Audio)	V	V		V																																										
WRANGLER	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
WRANGLER	2010	HFM (Hands Free Module)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
WRANGLER	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
WRANGLER	2010	ITM (Intrusion)	V			V																																										
WRANGLER	2010	ORC (Occupant Restraint Control)	V	V		V																																										
WRANGLER	2010	RADIO (Radio)	V	V		V																																										
WRANGLER	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
WRANGLER	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
WRANGLER	2010	CGW (Central Gateway)	V	V	V	V																																										
WRANGLER	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
WRANGLER	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
WRANGLER	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
WRANGLER	2009	AMP (Audio)	V	V		V																																										
WRANGLER	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
WRANGLER	2009	HFM (Hands Free Module)	V	V	V	V																																										
WRANGLER	2009	HVAC (Heat Vent A/C)	V	V	V	V																																										
WRANGLER	2009	ITM (Intrusion)	V			V																																										
WRANGLER	2009	ORC (Occupant Restraint Control)	V	V		V																																										
WRANGLER	2009	RADIO (Radio)	V	V		V																																										
WRANGLER	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
WRANGLER	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
WRANGLER	2009	CGW (Central Gateway)	V	V	V	V																																										
WRANGLER	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
WRANGLER	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
WRANGLER	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
WRANGLER	2008	AMP (Audio)	V	V		V																																										
WRANGLER	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
WRANGLER	2008	HVAC (Heat Vent A/C)	V	V	V	V																																										
WRANGLER	2008	ITM (Intrusion)	V			V																																										
WRANGLER	2008	ORC (Occupant Restraint Control)	V	V		V																																										
WRANGLER	2008	RADIO (Radio)	V	V		V																																										
WRANGLER	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
WRANGLER	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
WRANGLER	2008	CGW (Central Gateway)	V	V	V	V																																										
WRANGLER	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
WRANGLER	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
WRANGLER	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
WRANGLER	2007	AMP (Audio)	V	V		V																																										
WRANGLER	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
WRANGLER	2007	HVAC (Heat Vent A/C)	V	V	V	V																																										
WRANGLER	2007	ITM (Intrusion)	V			V																																										
WRANGLER	2007	OCM (Occupant Classification Module)	V			V																																										
WRANGLER	2007	ORC (Occupant Restraint Control)	V	V		V																																										
WRANGLER	2007	RADIO (Radio)	V	V		V																																										
WRANGLER	2007	SAS (Steering Angle Sensor)	V	V	V	V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
WRANGLER	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
WRANGLER	2007	CGW (Central Gateway)	V	V	V	V																																										
WRANGLER	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
COMPASS	2016	PCM (Powertrain Control Module)	V			V																																										
COMPASS	2016	ABS (Anti Lock Brake System)	V			V																																										
COMPASS	2016	AMP (Audio)	V			V																																										
COMPASS	2016	BCM (Body Control Module)	V			V																																										
COMPASS	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
COMPASS	2016	CGW (Central Gateway)	V			V																																										
COMPASS	2016	FDCM/AWD (Final Drive Control / All Wheel Drive)	V			V																																										
COMPASS	2016	HFM (Hands Free Module)	V			V																																										
COMPASS	2016	HVAC (Heat Vent A/C)	V			V																																										
COMPASS	2016	ITM (Intrusion)	V			V																																										
COMPASS	2016	ORC (Occupant Restraint Control)	V			V																																										
COMPASS	2016	RADIO (Radio)	V			V																																										
COMPASS	2016	RFH (Radio Frequency Hub)	V			V																																										
COMPASS	2016	SAS (Steering Angle Sensor)	V			V																																										
COMPASS	2016	TCM (Transmission Control Module)	V			V																																										
COMPASS	2016	WCM(Wireless Control Modules)	V			V																																										
COMPASS	2015	PCM (Powertrain Control Module)	V			V																																										
COMPASS	2015	ABS (Anti Lock Brake System)	V			V																																										
COMPASS	2015	AMP (Audio)	V			V																																										
COMPASS	2015	BCM (Body Control Module)	V			V																																										
COMPASS	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
COMPASS	2015	CGW (Central Gateway)	V			V																																										
COMPASS	2015	FDCM/AWD (Final Drive Control / All Wheel Drive)	V			V																																										
COMPASS	2015	HFM (Hands Free Module)	V			V																																										
COMPASS	2015	HVAC (Heat Vent A/C)	V			V																																										
COMPASS	2015	ITM (Intrusion)	V			V																																										
COMPASS	2015	ORC (Occupant Restraint Control)	V			V																																										
COMPASS	2015	RADIO (Radio)	V			V																																										
COMPASS	2015	RFH (Radio Frequency Hub)	V			V																																										
COMPASS	2015	SAS (Steering Angle Sensor)	V			V																																										
COMPASS	2015	TCM (Transmission Control Module)	V			V																																										
COMPASS	2015	WCM(Wireless Control Modules)	V			V																																										
COMPASS	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMPASS	2014	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
COMPASS	2014	AMP (Audio)	V	V		V																																										
COMPASS	2014	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
COMPASS	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMPASS	2014	HFM (Hands Free Module)	V	V	V	V																																										
COMPASS	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
COMPASS	2014	ITM (Intrusion)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
COMPASS	2014	ORC (Occupant Restraint Control)	V	V		V																																										
COMPASS	2014	RADIO (Radio)	V	V		V																																										
COMPASS	2014	SAS (Steering Angle Sensor)	V	V	V	V																																										
COMPASS	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
COMPASS	2014	CGW (Central Gateway)	V	V	V	V																																										
COMPASS	2014	WCM(Wireless Control Modules)	V	V	V	V																																										
COMPASS	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMPASS	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
COMPASS	2013	AMP (Audio)	V	V		V																																										
COMPASS	2013	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
COMPASS	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMPASS	2013	HFM (Hands Free Module)	V	V	V	V																																										
COMPASS	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
COMPASS	2013	ITM (Intrusion)	V			V																																										
COMPASS	2013	ORC (Occupant Restraint Control)	V	V		V																																										
COMPASS	2013	RADIO (Radio)	V	V		V																																										
COMPASS	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
COMPASS	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
COMPASS	2013	CGW (Central Gateway)	V	V	V	V																																										
COMPASS	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
COMPASS	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMPASS	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
COMPASS	2012	AMP (Audio)	V	V		V																																										
COMPASS	2012	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
COMPASS	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMPASS	2012	HFM (Hands Free Module)	V	V	V	V																																										
COMPASS	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
COMPASS	2012	ITM (Intrusion)	V			V																																										
COMPASS	2012	ORC (Occupant Restraint Control)	V	V		V																																										
COMPASS	2012	RADIO (Radio)	V	V		V																																										
COMPASS	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
COMPASS	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
COMPASS	2012	CGW (Central Gateway)	V	V	V	V																																										
COMPASS	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
COMPASS	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMPASS	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
COMPASS	2011	AMP (Audio)	V	V		V																																										
COMPASS	2011	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
COMPASS	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMPASS	2011	HFM (Hands Free Module)	V	V	V	V																																										
COMPASS	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
COMPASS	2011	ITM (Intrusion)	V			V																																										
COMPASS	2011	ORC (Occupant Restraint Control)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
COMPASS	2011	RADIO (Radio)	V	V		V																																										
COMPASS	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
COMPASS	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
COMPASS	2011	CGW (Central Gateway)	V	V	V	V																																										
COMPASS	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
COMPASS	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMPASS	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
COMPASS	2010	AMP (Audio)	V	V		V																																										
COMPASS	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
COMPASS	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMPASS	2010	HFM (Hands Free Module)	V	V	V	V																																										
COMPASS	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
COMPASS	2010	ITM (Intrusion)	V			V																																										
COMPASS	2010	ORC (Occupant Restraint Control)	V	V		V																																										
COMPASS	2010	RADIO (Radio)	V	V		V																																										
COMPASS	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
COMPASS	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
COMPASS	2010	CGW (Central Gateway)	V	V	V	V																																										
COMPASS	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
COMPASS	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMPASS	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
COMPASS	2009	AMP (Audio)	V	V		V																																										
COMPASS	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
COMPASS	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMPASS	2009	HFM (Hands Free Module)	V	V	V	V																																										
COMPASS	2009	ITM (Intrusion)	V			V																																										
COMPASS	2009	ORC (Occupant Restraint Control)	V	V		V																																										
COMPASS	2009	RADIO (Radio)	V	V		V																																										
COMPASS	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
COMPASS	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
COMPASS	2009	CGW (Central Gateway)	V	V	V	V																																										
COMPASS	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
COMPASS	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMPASS	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
COMPASS	2008	AMP (Audio)	V	V		V																																										
COMPASS	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
COMPASS	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMPASS	2008	HFM (Hands Free Module)	V	V	V	V																																										
COMPASS	2008	ITM (Intrusion)	V			V																																										
COMPASS	2008	ORC (Occupant Restraint Control)	V	V		V																																										
COMPASS	2008	RADIO (Radio)	V	V		V																																										
COMPASS	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
COMPASS	2008	SDAR (Satellite Radio)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
COMPASS	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
COMPASS	2008	CGW (Central Gateway)	V	V	V	V																																										
COMPASS	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
COMPASS	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
COMPASS	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
COMPASS	2007	AMP (Audio)	V	V		V																																										
COMPASS	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
COMPASS	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
COMPASS	2007	HFM (Hands Free Module)	V	V	V	V																																										
COMPASS	2007	ITM (Intrusion)	V			V																																										
COMPASS	2007	OCM (Occupant Classification Module)	V			V																																										
COMPASS	2007	ORC (Occupant Restraint Control)	V	V		V																																										
COMPASS	2007	RADIO (Radio)	V	V		V																																										
COMPASS	2007	SAS (Steering Angle Sensor)	V	V	V	V																																										
COMPASS	2007	SDAR (Satellite Radio)	V			V																																										
COMPASS	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
COMPASS	2007	CGW (Central Gateway)	V	V	V	V																																										
COMPASS	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
PATRIOT	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PATRIOT	2016	ABS (Anti Lock Brake System)	V			V																																										
PATRIOT	2016	AMP (Audio)	V			V																																										
PATRIOT	2016	BCM (Body Control Module)	V			V																																										
PATRIOT	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
PATRIOT	2016	CGW (Central Gateway)	V			V																																										
PATRIOT	2016	FDCM/AWD (Final Drive Control / All Wheel Drive)	V			V																																										
PATRIOT	2016	HFM (Hands Free Module)	V			V																																										
PATRIOT	2016	HVAC (Heat Vent A/C)	V			V																																										
PATRIOT	2016	ITM (Intrusion)	V			V																																										
PATRIOT	2016	ORC (Occupant Restraint Control)	V			V																																										
PATRIOT	2016	RADIO (Radio)	V			V																																										
PATRIOT	2016	RFH (Radio Frequency Hub)	V			V																																										
PATRIOT	2016	SAS (Steering Angle Sensor)	V			V																																										
PATRIOT	2016	TCM (Transmission Control Module)	V			V																																										
PATRIOT	2016	WCM(Wireless Control Modules)	V			V																																										
PATRIOT	2015	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PATRIOT	2015	ABS (Anti Lock Brake System)	V			V																																										
PATRIOT	2015	AMP (Audio)	V			V																																										
PATRIOT	2015	BCM (Body Control Module)	V			V																																										
PATRIOT	2015	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
PATRIOT	2015	CGW (Central Gateway)	V			V																																										
PATRIOT	2015	FDCM/AWD (Final Drive Control / All Wheel Drive)	V			V																																										
PATRIOT	2015	HFM (Hands Free Module)	V			V																																										
PATRIOT	2015	HVAC (Heat Vent A/C)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
PATRIOT	2015	ITM (Intrusion)	V			V																																										
PATRIOT	2015	ORC (Occupant Restraint Control)	V			V																																										
PATRIOT	2015	RADIO (Radio)	V			V																																										
PATRIOT	2015	RFH (Radio Frequency Hub)	V			V																																										
PATRIOT	2015	SAS (Steering Angle Sensor)	V			V																																										
PATRIOT	2015	TCM (Transmission Control Module)	V			V																																										
PATRIOT	2015	WCM(Wireless Control Modules)	V			V																																										
PATRIOT	2014	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PATRIOT	2014	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
PATRIOT	2014	AMP (Audio)	V	V		V																																										
PATRIOT	2014	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
PATRIOT	2014	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PATRIOT	2014	HFM (Hands Free Module)	V	V	V	V																																										
PATRIOT	2014	HVAC (Heat Vent A/C)	V	V	V	V																																										
PATRIOT	2014	ITM (Intrusion)	V			V																																										
PATRIOT	2014	ORC (Occupant Restraint Control)	V	V		V																																										
PATRIOT	2014	RADIO (Radio)	V	V		V																																										
PATRIOT	2014	SAS (Steering Angle Sensor)	V	V	V	V																																										
PATRIOT	2014	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
PATRIOT	2014	CGW (Central Gateway)	V	V	V	V																																										
PATRIOT	2014	WCM(Wireless Control Modules)	V	V	V	V																																										
PATRIOT	2013	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PATRIOT	2013	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
PATRIOT	2013	AMP (Audio)	V	V		V																																										
PATRIOT	2013	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
PATRIOT	2013	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PATRIOT	2013	HFM (Hands Free Module)	V	V	V	V																																										
PATRIOT	2013	HVAC (Heat Vent A/C)	V	V	V	V																																										
PATRIOT	2013	ITM (Intrusion)	V			V																																										
PATRIOT	2013	ORC (Occupant Restraint Control)	V	V		V																																										
PATRIOT	2013	RADIO (Radio)	V	V		V																																										
PATRIOT	2013	SAS (Steering Angle Sensor)	V	V	V	V																																										
PATRIOT	2013	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
PATRIOT	2013	CGW (Central Gateway)	V	V	V	V																																										
PATRIOT	2013	WCM(Wireless Control Modules)	V	V	V	V																																										
PATRIOT	2012	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PATRIOT	2012	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
PATRIOT	2012	AMP (Audio)	V	V		V																																										
PATRIOT	2012	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
PATRIOT	2012	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PATRIOT	2012	HFM (Hands Free Module)	V	V	V	V																																										
PATRIOT	2012	HVAC (Heat Vent A/C)	V	V	V	V																																										
PATRIOT	2012	ITM (Intrusion)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
PATRIOT	2012	ORC (Occupant Restraint Control)	V	V		V																																										
PATRIOT	2012	RADIO (Radio)	V	V		V																																										
PATRIOT	2012	SAS (Steering Angle Sensor)	V	V	V	V																																										
PATRIOT	2012	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
PATRIOT	2012	CGW (Central Gateway)	V	V	V	V																																										
PATRIOT	2012	WCM(Wireless Control Modules)	V	V	V	V																																										
PATRIOT	2011	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PATRIOT	2011	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
PATRIOT	2011	AMP (Audio)	V	V		V																																										
PATRIOT	2011	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
PATRIOT	2011	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PATRIOT	2011	HFM (Hands Free Module)	V	V	V	V																																										
PATRIOT	2011	HVAC (Heat Vent A/C)	V	V	V	V																																										
PATRIOT	2011	ITM (Intrusion)	V			V																																										
PATRIOT	2011	ORC (Occupant Restraint Control)	V	V		V																																										
PATRIOT	2011	RADIO (Radio)	V	V		V																																										
PATRIOT	2011	SAS (Steering Angle Sensor)	V	V	V	V																																										
PATRIOT	2011	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
PATRIOT	2011	CGW (Central Gateway)	V	V	V	V																																										
PATRIOT	2011	WCM(Wireless Control Modules)	V	V	V	V																																										
PATRIOT	2010	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PATRIOT	2010	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
PATRIOT	2010	AMP (Audio)	V	V		V																																										
PATRIOT	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
PATRIOT	2010	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PATRIOT	2010	HFM (Hands Free Module)	V	V	V	V																																										
PATRIOT	2010	HVAC (Heat Vent A/C)	V	V	V	V																																										
PATRIOT	2010	ITM (Intrusion)	V			V																																										
PATRIOT	2010	ORC (Occupant Restraint Control)	V	V		V																																										
PATRIOT	2010	RADIO (Radio)	V	V		V																																										
PATRIOT	2010	SAS (Steering Angle Sensor)	V	V	V	V																																										
PATRIOT	2010	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
PATRIOT	2010	CGW (Central Gateway)	V	V	V	V																																										
PATRIOT	2010	WCM(Wireless Control Modules)	V	V	V	V																																										
PATRIOT	2009	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PATRIOT	2009	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
PATRIOT	2009	AMP (Audio)	V	V		V																																										
PATRIOT	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
PATRIOT	2009	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PATRIOT	2009	HFM (Hands Free Module)	V	V	V	V																																										
PATRIOT	2009	ITM (Intrusion)	V			V																																										
PATRIOT	2009	ORC (Occupant Restraint Control)	V	V		V																																										
PATRIOT	2009	RADIO (Radio)	V	V		V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
PATRIOT	2009	SAS (Steering Angle Sensor)	V	V	V	V																																										
PATRIOT	2009	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
PATRIOT	2009	CGW (Central Gateway)	V	V	V	V																																										
PATRIOT	2009	WCM(Wireless Control Modules)	V	V	V	V																																										
PATRIOT	2008	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PATRIOT	2008	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
PATRIOT	2008	AMP (Audio)	V	V		V																																										
PATRIOT	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
PATRIOT	2008	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PATRIOT	2008	HFM (Hands Free Module)	V	V	V	V																																										
PATRIOT	2008	ITM (Intrusion)	V			V																																										
PATRIOT	2008	ORC (Occupant Restraint Control)	V	V		V																																										
PATRIOT	2008	RADIO (Radio)	V	V		V																																										
PATRIOT	2008	SAS (Steering Angle Sensor)	V	V	V	V																																										
PATRIOT	2008	SDAR (Satellite Radio)	V			V																																										
PATRIOT	2008	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
PATRIOT	2008	CGW (Central Gateway)	V	V	V	V																																										
PATRIOT	2008	WCM(Wireless Control Modules)	V	V	V	V																																										
PATRIOT	2007	PCM (Powertrain Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
PATRIOT	2007	ABS (Anti Lock Brake System)	V	V	V	V																																							V	V	V	V
PATRIOT	2007	AMP (Audio)	V	V		V																																										
PATRIOT	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)	V	V	V	V																																										
PATRIOT	2007	CCN (Instrument Cluster / Cabin Compartment Node)	V	V	V	V																																										
PATRIOT	2007	HFM (Hands Free Module)	V	V	V	V																																										
PATRIOT	2007	ITM (Intrusion)	V			V																																										
PATRIOT	2007	OCM (Occupant Classification Module)	V			V																																										
PATRIOT	2007	ORC (Occupant Restraint Control)	V	V		V																																										
PATRIOT	2007	RADIO (Radio)	V	V		V																																										
PATRIOT	2007	SAS (Steering Angle Sensor)	V	V	V	V																																										
PATRIOT	2007	SDAR (Satellite Radio)	V			V																																										
PATRIOT	2007	TCM (Transmission Control Module)	V	V	V	V	V																																V	V	V	V	V	V				
PATRIOT	2007	CGW (Central Gateway)	V	V	V	V																																										
PATRIOT	2007	WCM(Wireless Control Modules)	V	V	V	V																																										
RENEGADE	2016	PCM (Powertrain Control Module)	V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										
RENEGADE	2016	ABS (Anti Lock Brake System)	V			V																																										
RENEGADE	2016	ACC (Adaptive Cruise Control)	V			V																																										
RENEGADE	2016	AMP (Audio)	V			V																																										
RENEGADE	2016	BCM (Body Control Module)	V			V																																										
RENEGADE	2016	CCN (Instrument Cluster / Cabin Compartment Node)	V			V																																										
RENEGADE	2016	CGW (Central Gateway)	V			V																																										
RENEGADE	2016	DDM (Drivers Door Module)	V			V																																										
RENEGADE	2016	DTCM (Drive Train Control Module)	V			V																																										
RENEGADE	2016	EDM (Electronic Damper Module)	V			V																																										

Vehicle	Year	System	DTC	Sensor	ACT	ECU Info	VIN Writing	Compression Test	Cylinder Balance Test	Cylinder Fuel Quantity Correction Test	Injector Kill System Test	Set RPM Test	Generator Full Field Test	ETC System Test	Purge Vapors System Test	Adaptive Numerator Learn	ETC Throttle Follower Test	Reset Memory	EGR System Test	O2 Heater System Test	SRV Test	Clear Learned Variable Line Pressure (VLP) Counters	TCC Break-In	Cam Crank Relearn	Stationary Desoot	View/Reset Trip Information Accumulators	View/Reset Duty Cycle Accumulators	Auxiliary Fuel Filter Enable	Reset Aftertreatment Trip Information	Reset Regenerative Filter Timers	Reset NOx Adsorber Counts	Enable / Disable Vehicle Features	View/Reset Duty Cycle Maps	Intake Phaser 1 Cleaning	Exhaust Phaser 1 Cleaning	Exhaust Phaser 2 Cleaning	Intake Phaser 2 Cleaning	NVLD Forced Monitor Test	Clear Learned Values	TCC Break-In	TCM Initialization	Clear Learned Variable Line Pressure Counters	Reset Learned Adaptives	Store Learned Adaptives	Bleed Brakes	ABS Initialization	Initialize ECU	Initialize Steering Angle Sensor
RENEGADE	2016	EPS (Electric Power Steering)	V			V																																										
RENEGADE	2016	ESM (Electronic Shifter Module)	V			V																																										
RENEGADE	2016	FFCM (Front Facing Camera Module)	V	V	V	V																																										
RENEGADE	2016	HVAC (Heat Vent A/C)	V			V																																										
RENEGADE	2016	ICS (Integrated Center Stack)	V			V																																										
RENEGADE	2016	IPC (Instrument Panel Cluster)	V			V																																										
RENEGADE	2016	LBSS (Left Blind Spot Sensor)	V			V																																										
RENEGADE	2016	MSMD (Memory Seet Module)	V			V																																										
RENEGADE	2016	OCM (Occupant Classification Module)	V			V																																										
RENEGADE	2016	ORC (Occupant Restraint Control)	V			V																																										
RENEGADE	2016	PDM (Passenger Door Module)	V			V																																										
RENEGADE	2016	PLM (Power Liftgate Module)	V			V																																										
RENEGADE	2016	RADIO (Radio)	V			V																																										
RENEGADE	2016	RBSS (Right Blind Spot Sensor)	V			V																																										
RENEGADE	2016	RFH (Radio Frequency Hub)	V			V																																										
RENEGADE	2016	SCM (Steering Column Module)	V			V																																										
RENEGADE	2016	TCM (Transmission Control Module)	V			V																																										
RENEGADE	2016	WCM(Wireless Control Modules)	V			V																																										

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
General(CAN Bus)	ALL	PCM (Powertrain Control Module)																																														
General(CAN Bus)	ALL	ABS (Anti Lock Brake System)	V																																													
General(CAN Bus)	ALL	ACC (Adaptive Cruise Control)																																														
General(CAN Bus)	ALL	ADCM (Adaptive Damper Control Module)																																														
General(CAN Bus)	ALL	AFLS (Adaptive Front Light System)																																														
General(CAN Bus)	ALL	AHBM (Automatic High Beam)																																														
General(CAN Bus)	ALL	AMP (Audio)																						V	V																							
General(CAN Bus)	ALL	BCM (Body Control Module)																																														
General(CAN Bus)	ALL	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
General(CAN Bus)	ALL	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
General(CAN Bus)	ALL	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
General(CAN Bus)	ALL	DDM (Drivers Door Module)																					V																										
General(CAN Bus)	ALL	DTCM (Drive Train Control Module)																																														
General(CAN Bus)	ALL	EDM (Electronic Damper Module)																																														
General(CAN Bus)	ALL	EOM (Electric Overhead Module)																																											V			
General(CAN Bus)	ALL	EPB (Electrical Parking Brake)																																														V
General(CAN Bus)	ALL	EPS (Electric Power Steering)																																														
General(CAN Bus)	ALL	ESM (Electronic Shifter Module)																																														
General(CAN Bus)	ALL	FFCM (Front Facing Camera Module)																																													V	
General(CAN Bus)	ALL	HFM (Hands Free Module)																																								V						
General(CAN Bus)	ALL	HSM (Heated Seat Module)																																														
General(CAN Bus)	ALL	HVAC (Heat Vent A/C)																								V	V	V	V																			
General(CAN Bus)	ALL	ICS (Integrated Center Stack)																																														
General(CAN Bus)	ALL	IPC (Instrument Panel Cluster)																																														
General(CAN Bus)	ALL	ITM (Intrusion)																																														
General(CAN Bus)	ALL	LBSS (Left Blind Spot Sensor)																																														
General(CAN Bus)	ALL	LRSM (Light Rain Sensor Module)																																														
General(CAN Bus)	ALL	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
General(CAN Bus)	ALL	OCM (Occupant Classification Module)																																														
General(CAN Bus)	ALL	ORC (Occupant Restraint Control)		V																																												
General(CAN Bus)	ALL	PDM (Passenger Door Module)																																														
General(CAN Bus)	ALL	PLM (Power Liftgate Module)																																														
General(CAN Bus)	ALL	PTS (Park Assist Module)																																														
General(CAN Bus)	ALL	RADIO (Radio)																																				V	V	V	V							
General(CAN Bus)	ALL	RBSS (Right Blind Spot Sensor)																																														
General(CAN Bus)	ALL	RFH (Radio Frequency Hub)																																														
General(CAN Bus)	ALL	SAS (Steering Angle Sensor)																																														
General(CAN Bus)	ALL	SCM (Steering Column Module)																																														
General(CAN Bus)	ALL	SDAR (Satellite Radio)																																														
General(CAN Bus)	ALL	SUNR (Sunroof Module)																																														
General(CAN Bus)	ALL	TCM (Transmission Control Module)																																														
General(CAN Bus)	ALL	TGW (Telematics Gateway)																																														
General(CAN Bus)	ALL	TPM (Tire Pressure Monitor)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
General(CAN Bus)	ALL	VES3 (Vidio Entertainment System 3)																																														
General(CAN Bus)	ALL	WCM(Wireless Control Modules)														V																											V	V			
CHEROKEE	2016	PCM (Powertrain Control Module)																																														
CHEROKEE	2016	ABS (Anti Lock Brake System)																																														
CHEROKEE	2016	ACC (Adaptive Cruise Control)																																														
CHEROKEE	2016	AMP (Audio)																																														
CHEROKEE	2016	BCM (Body Control Module)																																														
CHEROKEE	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
CHEROKEE	2016	CGW (Central Gateway)																																														
CHEROKEE	2016	DDM (Drivers Door Module)																																														
CHEROKEE	2016	DTCM (Drive Train Control Module)																																														
CHEROKEE	2016	EDM (Electronic Damper Module)																																														
CHEROKEE	2016	EPB (Electrical Parking Brake)																																														V
CHEROKEE	2016	EPS (Electric Power Steering)																																														
CHEROKEE	2016	ESM (Electronic Shifter Module)																																														
CHEROKEE	2016	FFCM (Front Facing Camera Module)																																													V	
CHEROKEE	2016	HVAC (Heat Vent A/C)																																														
CHEROKEE	2016	ICS (Integrated Center Stack)																																														
CHEROKEE	2016	IPC (Instrument Panel Cluster)																																														
CHEROKEE	2016	LBSS (Left Blind Spot Sensor)																																														
CHEROKEE	2016	MSMD (Memory Seet Module)																																														
CHEROKEE	2016	OCM (Occupant Classification Module)																																														
CHEROKEE	2016	ORC (Occupant Restraint Control)																																														
CHEROKEE	2016	PDM (Passenger Door Module)																																														
CHEROKEE	2016	PLM (Power Liftgate Module)																																														
CHEROKEE	2016	RADIO (Radio)																																														
CHEROKEE	2016	RBSS (Right Blind Spot Sensor)																																														
CHEROKEE	2016	RFH (Radio Frequency Hub)																																														
CHEROKEE	2016	SCM (Steering Column Module)																																														
CHEROKEE	2016	TCM (Transmission Control Module)																																														
CHEROKEE	2016	WCM(Wireless Control Modules)																																														
CHEROKEE	2015	PCM (Powertrain Control Module)																																														
CHEROKEE	2015	ABS (Anti Lock Brake System)																																														
CHEROKEE	2015	ACC (Adaptive Cruise Control)																																														
CHEROKEE	2015	AMP (Audio)																																														
CHEROKEE	2015	BCM (Body Control Module)																																														
CHEROKEE	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
CHEROKEE	2015	CGW (Central Gateway)																																														
CHEROKEE	2015	DDM (Drivers Door Module)																																														
CHEROKEE	2015	DTCM (Drive Train Control Module)																																														
CHEROKEE	2015	EDM (Electronic Damper Module)																																														
CHEROKEE	2015	EPB (Electrical Parking Brake)																																														V
CHEROKEE	2015	EPS (Electric Power Steering)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CHEROKEE	2015	ESM (Electronic Shifter Module)																																													
CHEROKEE	2015	FFCM (Front Facing Camera Module)																																												V	
CHEROKEE	2015	HVAC (Heat Vent A/C)																																													
CHEROKEE	2015	ICS (Integrated Center Stack)																																													
CHEROKEE	2015	IPC (Instrument Panel Cluster)																																													
CHEROKEE	2015	LBSS (Left Blind Spot Sensor)																																													
CHEROKEE	2015	MSMD (Memory Seet Module)																																													
CHEROKEE	2015	OCM (Occupant Classification Module)																																													
CHEROKEE	2015	ORC (Occupant Restraint Control)																																													
CHEROKEE	2015	PDM (Passenger Door Module)																																													
CHEROKEE	2015	PLM (Power Liftgate Module)																																													
CHEROKEE	2015	RADIO (Radio)																																													
CHEROKEE	2015	RBSS (Right Blind Spot Sensor)																																													
CHEROKEE	2015	RFH (Radio Frequency Hub)																																													
CHEROKEE	2015	SCM (Steering Column Module)																																													
CHEROKEE	2015	TCM (Transmission Control Module)																																													
CHEROKEE	2015	WCM(Wireless Control Modules)																																													
CHEROKEE	2014	PCM (Powertrain Control Module)																																													
CHEROKEE	2014	ABS (Anti Lock Brake System)																																													
CHEROKEE	2014	ACC (Adaptive Cruise Control)																																													
CHEROKEE	2014	AMP (Audio)																																													
CHEROKEE	2014	BCM (Body Control Module)																																													
CHEROKEE	2014	CCN (Instrument Cluster / Cabin Compartment Node)																																													
CHEROKEE	2014	CGW (Central Gateway)																																													
CHEROKEE	2014	DDM (Drivers Door Module)																																													
CHEROKEE	2014	DTCM (Drive Train Control Module)																																													
CHEROKEE	2014	EDM (Electronic Damper Module)																																													
CHEROKEE	2014	EPB (Electrical Parking Brake)																																													V
CHEROKEE	2014	EPS (Electric Power Steering)																																													
CHEROKEE	2014	ESM (Electronic Shifter Module)																																													
CHEROKEE	2014	FFCM (Front Facing Camera Module)																																												V	
CHEROKEE	2014	HVAC (Heat Vent A/C)																																													
CHEROKEE	2014	ICS (Integrated Center Stack)																																													
CHEROKEE	2014	IPC (Instrument Panel Cluster)																																													
CHEROKEE	2014	LBSS (Left Blind Spot Sensor)																																													
CHEROKEE	2014	MSMD (Memory Seet Module)																																													
CHEROKEE	2014	OCM (Occupant Classification Module)																																													
CHEROKEE	2014	ORC (Occupant Restraint Control)																																													
CHEROKEE	2014	PDM (Passenger Door Module)																																													
CHEROKEE	2014	PLM (Power Liftgate Module)																																													
CHEROKEE	2014	RADIO (Radio)																																													
CHEROKEE	2014	RBSS (Right Blind Spot Sensor)																																													
CHEROKEE	2014	RFH (Radio Frequency Hub)																																													

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
CHEROKEE	2014	SCM (Steering Column Module)																																														
CHEROKEE	2014	TCM (Transmission Control Module)																																														
CHEROKEE	2014	WCM(Wireless Control Modules)																																														
GRAND CHEROKEE	2016	PCM (Powertrain Control Module)																																														
GRAND CHEROKEE	2016	ABS (Anti Lock Brake System)																																														
GRAND CHEROKEE	2016	ACC (Adaptive Cruise Control)																																														
GRAND CHEROKEE	2016	ADCM (Adaptive Damper Control Module)																																														
GRAND CHEROKEE	2016	AFLS (Adaptive Front Light System)																																														
GRAND CHEROKEE	2016	AMP (Audio)																																														
GRAND CHEROKEE	2016	BCM (Body Control Module)																																														
GRAND CHEROKEE	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
GRAND CHEROKEE	2016	CGW (Central Gateway)																																														
GRAND CHEROKEE	2016	DDM (Drivers Door Module)																																														
GRAND CHEROKEE	2016	DTCM (Drive Train Control Module)																																														
GRAND CHEROKEE	2016	EDM (Electronic Damper Module)																																														
GRAND CHEROKEE	2016	EPS (Electric Power Steering)																																														
GRAND CHEROKEE	2016	ESM (Electronic Shifter Module)																																														
GRAND CHEROKEE	2016	FFCM (Front Facing Camera Module)																																													V	
GRAND CHEROKEE	2016	HSM (Heated Seat Module)																																														
GRAND CHEROKEE	2016	HVAC (Heat Vent A/C)																																														
GRAND CHEROKEE	2016	ICS (Integrated Center Stack)																																														
GRAND CHEROKEE	2016	IPC (Instrument Panel Cluster)																																														
GRAND CHEROKEE	2016	ITM (Intrusion)																																														
GRAND CHEROKEE	2016	LBSS (Left Blind Spot Sensor)																																														
GRAND CHEROKEE	2016	MSMD (Memory Seet Module)																																														
GRAND CHEROKEE	2016	ORC (Occupant Restraint Control)																																														
GRAND CHEROKEE	2016	PDM (Passenger Door Module)																																														
GRAND CHEROKEE	2016	PLM (Power Liftgate Module)																																														
GRAND CHEROKEE	2016	PTS (Park Assist Module)																																														
GRAND CHEROKEE	2016	RADIO (Radio)																																														
GRAND CHEROKEE	2016	RBSS (Right Blind Spot Sensor)																																														
GRAND CHEROKEE	2016	RFH (Radio Frequency Hub)																																														
GRAND CHEROKEE	2016	SCM (Steering Column Module)																																														
GRAND CHEROKEE	2016	TCM (Transmission Control Module)																																														
GRAND CHEROKEE	2016	WCM(Wireless Control Modules)																																														
GRAND CHEROKEE	2015	PCM (Powertrain Control Module)																																														
GRAND CHEROKEE	2015	ABS (Anti Lock Brake System)																																														
GRAND CHEROKEE	2015	ACC (Adaptive Cruise Control)																																														
GRAND CHEROKEE	2015	ADCM (Adaptive Damper Control Module)																																														
GRAND CHEROKEE	2015	AFLS (Adaptive Front Light System)																																														
GRAND CHEROKEE	2015	AMP (Audio)																																														
GRAND CHEROKEE	2015	BCM (Body Control Module)																																														
GRAND CHEROKEE	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND CHEROKEE	2015	CGW (Central Gateway)																																														
GRAND CHEROKEE	2015	DDM (Drivers Door Module)																																														
GRAND CHEROKEE	2015	DTCM (Drive Train Control Module)																																														
GRAND CHEROKEE	2015	EDM (Electronic Damper Module)																																														
GRAND CHEROKEE	2015	EPS (Electric Power Steering)																																														
GRAND CHEROKEE	2015	ESM (Electronic Shifter Module)																																														
GRAND CHEROKEE	2015	FFCM (Front Facing Camera Module)																																													V	
GRAND CHEROKEE	2015	HSM (Heated Seat Module)																																														
GRAND CHEROKEE	2015	HVAC (Heat Vent A/C)																																														
GRAND CHEROKEE	2015	ICS (Integrated Center Stack)																																														
GRAND CHEROKEE	2015	IPC (Instrument Panel Cluster)																																														
GRAND CHEROKEE	2015	ITM (Intrusion)																																														
GRAND CHEROKEE	2015	LBSS (Left Blind Spot Sensor)																																														
GRAND CHEROKEE	2015	MSMD (Memory Seet Module)																																														
GRAND CHEROKEE	2015	ORC (Occupant Restraint Control)																																														
GRAND CHEROKEE	2015	PDM (Passenger Door Module)																																														
GRAND CHEROKEE	2015	PLM (Power Liftgate Module)																																														
GRAND CHEROKEE	2015	PTS (Park Assist Module)																																														
GRAND CHEROKEE	2015	RADIO (Radio)																																														
GRAND CHEROKEE	2015	RBSS (Right Blind Spot Sensor)																																														
GRAND CHEROKEE	2015	RFH (Radio Frequency Hub)																																														
GRAND CHEROKEE	2015	SCM (Steering Column Module)																																														
GRAND CHEROKEE	2015	TCM (Transmission Control Module)																																														
GRAND CHEROKEE	2015	WCM(Wireless Control Modules)																																														
GRAND CHEROKEE	2014	PCM (Powertrain Control Module)																																														
GRAND CHEROKEE	2014	ABS (Anti Lock Brake System)	V																																													
GRAND CHEROKEE	2014	ACC (Adaptive Cruise Control)																																														
GRAND CHEROKEE	2014	AMP (Audio)																						V	V																							
GRAND CHEROKEE	2014	DDM (Drivers Door Module)																					V																									
GRAND CHEROKEE	2014	DTCM (Drive Train Control Module)																																														
GRAND CHEROKEE	2014	ESM (Electronic Shifter Module)																																														
GRAND CHEROKEE	2014	HSM (Heated Seat Module)																																														
GRAND CHEROKEE	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CHEROKEE	2014	ITM (Intrusion)																																														
GRAND CHEROKEE	2014	ORC (Occupant Restraint Control)		V																																												
GRAND CHEROKEE	2014	PDM (Passenger Door Module)																																														
GRAND CHEROKEE	2014	PLM (Power Liftgate Module)																																														
GRAND CHEROKEE	2014	PTS (Park Assist Module)																																														
GRAND CHEROKEE	2014	RADIO (Radio)																																				V	V	V	V							
GRAND CHEROKEE	2014	TCM (Transmission Control Module)																																														
GRAND CHEROKEE	2014	TPM (Tire Pressure Monitor)																																														
GRAND CHEROKEE	2014	VES3 (Vidio Entertainment System 3)																																														
GRAND CHEROKEE	2013	PCM (Powertrain Control Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND CHEROKEE	2013	ABS (Anti Lock Brake System)	V																																													
GRAND CHEROKEE	2013	ACC (Adaptive Cruise Control)																																														
GRAND CHEROKEE	2013	AHBM (Automatic High Beam)																																														
GRAND CHEROKEE	2013	AMP (Audio)																						V	V																							
GRAND CHEROKEE	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CHEROKEE	2013	DTCM (Drive Train Control Module)																																														
GRAND CHEROKEE	2013	ESM (Electronic Shifter Module)																																														
GRAND CHEROKEE	2013	HFM (Hands Free Module)																																								V						
GRAND CHEROKEE	2013	HSM (Heated Seat Module)																																														
GRAND CHEROKEE	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CHEROKEE	2013	ITM (Intrusion)																																														
GRAND CHEROKEE	2013	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CHEROKEE	2013	ORC (Occupant Restraint Control)		V																																												
GRAND CHEROKEE	2013	PLM (Power Liftgate Module)																																														
GRAND CHEROKEE	2013	PTS (Park Assist Module)																																														
GRAND CHEROKEE	2013	RADIO (Radio)																																				V	V	V	V							
GRAND CHEROKEE	2013	SAS (Steering Angle Sensor)																																														
GRAND CHEROKEE	2013	TCM (Transmission Control Module)																																														
GRAND CHEROKEE	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
GRAND CHEROKEE	2013	TPM (Tire Pressure Monitor)																																														
GRAND CHEROKEE	2013	VES3 (Vidio Entertainment System 3)																																														
GRAND CHEROKEE	2013	WCM(Wireless Control Modules)														V																											V	V				
GRAND CHEROKEE	2012	PCM (Powertrain Control Module)																																														
GRAND CHEROKEE	2012	ABS (Anti Lock Brake System)	V																																													
GRAND CHEROKEE	2012	ACC (Adaptive Cruise Control)																																														
GRAND CHEROKEE	2012	AHBM (Automatic High Beam)																																														
GRAND CHEROKEE	2012	AMP (Audio)																						V	V																							
GRAND CHEROKEE	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CHEROKEE	2012	DTCM (Drive Train Control Module)																																														
GRAND CHEROKEE	2012	ESM (Electronic Shifter Module)																																														
GRAND CHEROKEE	2012	HFM (Hands Free Module)																																								V						
GRAND CHEROKEE	2012	HSM (Heated Seat Module)																																														
GRAND CHEROKEE	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CHEROKEE	2012	ITM (Intrusion)																																														
GRAND CHEROKEE	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CHEROKEE	2012	ORC (Occupant Restraint Control)		V																																												
GRAND CHEROKEE	2012	PLM (Power Liftgate Module)																																														
GRAND CHEROKEE	2012	PTS (Park Assist Module)																																														
GRAND CHEROKEE	2012	RADIO (Radio)																																				V	V	V	V							
GRAND CHEROKEE	2012	SAS (Steering Angle Sensor)																																														
GRAND CHEROKEE	2012	TCM (Transmission Control Module)																																														
GRAND CHEROKEE	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
GRAND CHEROKEE	2012	TPM (Tire Pressure Monitor)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND CHEROKEE	2012	VES3 (Vidio Entertainment System 3)																																														
GRAND CHEROKEE	2012	WCM(Wireless Control Modules)														V																											V	V			
GRAND CHEROKEE	2011	PCM (Powertrain Control Module)																																														
GRAND CHEROKEE	2011	ABS (Anti Lock Brake System)	V																																													
GRAND CHEROKEE	2011	ACC (Adaptive Cruise Control)																																														
GRAND CHEROKEE	2011	AHBM (Automatic High Beam)																																														
GRAND CHEROKEE	2011	AMP (Audio)																						V	V																							
GRAND CHEROKEE	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CHEROKEE	2011	DTCM (Drive Train Control Module)																																														
GRAND CHEROKEE	2011	ESM (Electronic Shifter Module)																																														
GRAND CHEROKEE	2011	HFM (Hands Free Module)																																								V						
GRAND CHEROKEE	2011	HSM (Heated Seat Module)																																														
GRAND CHEROKEE	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CHEROKEE	2011	ITM (Intrusion)																																														
GRAND CHEROKEE	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CHEROKEE	2011	ORC (Occupant Restraint Control)		V																																												
GRAND CHEROKEE	2011	PLM (Power Liftgate Module)																																														
GRAND CHEROKEE	2011	PTS (Park Assist Module)																																														
GRAND CHEROKEE	2011	RADIO (Radio)																																				V	V	V	V							
GRAND CHEROKEE	2011	SAS (Steering Angle Sensor)																																														
GRAND CHEROKEE	2011	TCM (Transmission Control Module)																																														
GRAND CHEROKEE	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
GRAND CHEROKEE	2011	TPM (Tire Pressure Monitor)																																														
GRAND CHEROKEE	2011	VES3 (Vidio Entertainment System 3)																																														
GRAND CHEROKEE	2011	WCM(Wireless Control Modules)														V																											V	V			
GRAND CHEROKEE	2010	PCM (Powertrain Control Module)																																														
GRAND CHEROKEE	2010	ABS (Anti Lock Brake System)	V																																													
GRAND CHEROKEE	2010	AHBM (Automatic High Beam)																																														
GRAND CHEROKEE	2010	AMP (Audio)																						V	V																							
GRAND CHEROKEE	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CHEROKEE	2010	DDM (Drivers Door Module)																					V																									
GRAND CHEROKEE	2010	EOM (Electric Overhead Module)																																											V			
GRAND CHEROKEE	2010	ESM (Electronic Shifter Module)																																														
GRAND CHEROKEE	2010	HFM (Hands Free Module)																																								V						
GRAND CHEROKEE	2010	HSM (Heated Seat Module)																																														
GRAND CHEROKEE	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CHEROKEE	2010	ITM (Intrusion)																																														
GRAND CHEROKEE	2010	LRSM (Light Rain Sensor Module)																																														
GRAND CHEROKEE	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CHEROKEE	2010	ORC (Occupant Restraint Control)		V																																												
GRAND CHEROKEE	2010	PDM (Passenger Door Module)																																														
GRAND CHEROKEE	2010	PTS (Park Assist Module)																																														
GRAND CHEROKEE	2010	RADIO (Radio)																																				V	V	V	V							

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND CHEROKEE	2010	SAS (Steering Angle Sensor)																																														
GRAND CHEROKEE	2010	SUNR (Sunroof Module)																																														
GRAND CHEROKEE	2010	TCM (Transmission Control Module)																																														
GRAND CHEROKEE	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
GRAND CHEROKEE	2010	VES3 (Vidio Entertainment System 3)																																														
GRAND CHEROKEE	2010	WCM(Wireless Control Modules)														V																											V	V			
GRAND CHEROKEE	2009	PCM (Powertrain Control Module)																																														
GRAND CHEROKEE	2009	ABS (Anti Lock Brake System)	V																																													
GRAND CHEROKEE	2009	AHBM (Automatic High Beam)																																														
GRAND CHEROKEE	2009	AMP (Audio)																						V	V																							
GRAND CHEROKEE	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CHEROKEE	2009	DDM (Drivers Door Module)																					V																									
GRAND CHEROKEE	2009	EOM (Electric Overhead Module)																																											V			
GRAND CHEROKEE	2009	ESM (Electronic Shifter Module)																																														
GRAND CHEROKEE	2009	HFM (Hands Free Module)																																								V						
GRAND CHEROKEE	2009	HSM (Heated Seat Module)																																														
GRAND CHEROKEE	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CHEROKEE	2009	ITM (Intrusion)																																														
GRAND CHEROKEE	2009	LRSM (Light Rain Sensor Module)																																														
GRAND CHEROKEE	2009	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CHEROKEE	2009	ORC (Occupant Restraint Control)		V																																												
GRAND CHEROKEE	2009	PDM (Passenger Door Module)																																														
GRAND CHEROKEE	2009	PTS (Park Assist Module)																																														
GRAND CHEROKEE	2009	RADIO (Radio)																																				V	V	V	V							
GRAND CHEROKEE	2009	SAS (Steering Angle Sensor)																																														
GRAND CHEROKEE	2009	SUNR (Sunroof Module)																																														
GRAND CHEROKEE	2009	TCM (Transmission Control Module)																																														
GRAND CHEROKEE	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
GRAND CHEROKEE	2009	VES3 (Vidio Entertainment System 3)																																														
GRAND CHEROKEE	2009	WCM(Wireless Control Modules)														V																											V	V			
GRAND CHEROKEE	2008	PCM (Powertrain Control Module)																																														
GRAND CHEROKEE	2008	ABS (Anti Lock Brake System)	V																																													
GRAND CHEROKEE	2008	AHBM (Automatic High Beam)																																														
GRAND CHEROKEE	2008	AMP (Audio)																						V	V																							
GRAND CHEROKEE	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CHEROKEE	2008	DDM (Drivers Door Module)																					V																									
GRAND CHEROKEE	2008	EOM (Electric Overhead Module)																																											V			
GRAND CHEROKEE	2008	ESM (Electronic Shifter Module)																																														
GRAND CHEROKEE	2008	HFM (Hands Free Module)																																								V						
GRAND CHEROKEE	2008	HSM (Heated Seat Module)																																														
GRAND CHEROKEE	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CHEROKEE	2008	ITM (Intrusion)																																														
GRAND CHEROKEE	2008	LRSM (Light Rain Sensor Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND CHEROKEE	2008	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CHEROKEE	2008	ORC (Occupant Restraint Control)		V																																												
GRAND CHEROKEE	2008	PDM (Passenger Door Module)																																														
GRAND CHEROKEE	2008	PTS (Park Assist Module)																																														
GRAND CHEROKEE	2008	RADIO (Radio)																																				V	V	V	V							
GRAND CHEROKEE	2008	SAS (Steering Angle Sensor)																																														
GRAND CHEROKEE	2008	SUNR (Sunroof Module)																																														
GRAND CHEROKEE	2008	TCM (Transmission Control Module)																																														
GRAND CHEROKEE	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND CHEROKEE	2008	VES3 (Vidio Entertainment System 3)																																														
GRAND CHEROKEE	2008	WCM(Wireless Control Modules)														V																											V	V				
GRAND CHEROKEE	2007	PCM (Powertrain Control Module)																																														
GRAND CHEROKEE	2007	ABS (Anti Lock Brake System)	V																																													
GRAND CHEROKEE	2007	AHBM (Automatic High Beam)																																														
GRAND CHEROKEE	2007	AMP (Audio)																						V	V																							
GRAND CHEROKEE	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CHEROKEE	2007	DDM (Drivers Door Module)																					V																									
GRAND CHEROKEE	2007	EOM (Electric Overhead Module)																																												V		
GRAND CHEROKEE	2007	ESM (Electronic Shifter Module)																																														
GRAND CHEROKEE	2007	HFM (Hands Free Module)																																								V						
GRAND CHEROKEE	2007	HSM (Heated Seat Module)																																														
GRAND CHEROKEE	2007	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CHEROKEE	2007	ITM (Intrusion)																																														
GRAND CHEROKEE	2007	LRSM (Light Rain Sensor Module)																																														
GRAND CHEROKEE	2007	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CHEROKEE	2007	ORC (Occupant Restraint Control)		V																																												
GRAND CHEROKEE	2007	PDM (Passenger Door Module)																																														
GRAND CHEROKEE	2007	PTS (Park Assist Module)																																														
GRAND CHEROKEE	2007	RADIO (Radio)																																				V	V	V	V							
GRAND CHEROKEE	2007	SCM (Steering Column Module)																																														
GRAND CHEROKEE	2007	SDAR (Satellite Radio)																																														
GRAND CHEROKEE	2007	SUNR (Sunroof Module)																																														
GRAND CHEROKEE	2007	TCM (Transmission Control Module)																																														
GRAND CHEROKEE	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND CHEROKEE	2007	WCM(Wireless Control Modules)														V																											V	V				
GRAND CHEROKEE	2006	PCM (Powertrain Control Module)																																														
GRAND CHEROKEE	2006	ABS (Anti Lock Brake System)	V																																													
GRAND CHEROKEE	2006	AHBM (Automatic High Beam)																																														
GRAND CHEROKEE	2006	AMP (Audio)																						V	V																							
GRAND CHEROKEE	2006	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CHEROKEE	2006	DDM (Drivers Door Module)																					V																									
GRAND CHEROKEE	2006	EOM (Electric Overhead Module)																																												V		
GRAND CHEROKEE	2006	ESM (Electronic Shifter Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
GRAND CHEROKEE	2006	HFM (Hands Free Module)																																								V						
GRAND CHEROKEE	2006	HSM (Heated Seat Module)																																														
GRAND CHEROKEE	2006	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CHEROKEE	2006	ITM (Intrusion)																																														
GRAND CHEROKEE	2006	LRSM (Light Rain Sensor Module)																																														
GRAND CHEROKEE	2006	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CHEROKEE	2006	OCM (Occupant Classification Module)																																														
GRAND CHEROKEE	2006	ORC (Occupant Restraint Control)		V																																												
GRAND CHEROKEE	2006	PDM (Passenger Door Module)																																														
GRAND CHEROKEE	2006	PTS (Park Assist Module)																																														
GRAND CHEROKEE	2006	RADIO (Radio)																																				V	V	V	V							
GRAND CHEROKEE	2006	SCM (Steering Column Module)																																														
GRAND CHEROKEE	2006	SDAR (Satellite Radio)																																														
GRAND CHEROKEE	2006	SUNR (Sunroof Module)																																														
GRAND CHEROKEE	2006	TCM (Transmission Control Module)																																														
GRAND CHEROKEE	2006	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND CHEROKEE	2006	WCM(Wireless Control Modules)														V																											V	V				
GRAND CHEROKEE	2005	PCM (Powertrain Control Module)																																														
GRAND CHEROKEE	2005	ABS (Anti Lock Brake System)	V																																													
GRAND CHEROKEE	2005	AHBM (Automatic High Beam)																																														
GRAND CHEROKEE	2005	AMP (Audio)																						V	V																							
GRAND CHEROKEE	2005	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
GRAND CHEROKEE	2005	DDM (Drivers Door Module)																					V																										
GRAND CHEROKEE	2005	EOM (Electric Overhead Module)																																											V			
GRAND CHEROKEE	2005	ESM (Electronic Shifter Module)																																														
GRAND CHEROKEE	2005	HFM (Hands Free Module)																																								V						
GRAND CHEROKEE	2005	HSM (Heated Seat Module)																																														
GRAND CHEROKEE	2005	HVAC (Heat Vent A/C)																								V	V	V	V																			
GRAND CHEROKEE	2005	ITM (Intrusion)																																														
GRAND CHEROKEE	2005	LRSM (Light Rain Sensor Module)																																														
GRAND CHEROKEE	2005	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
GRAND CHEROKEE	2005	OCM (Occupant Classification Module)																																														
GRAND CHEROKEE	2005	ORC (Occupant Restraint Control)		V																																												
GRAND CHEROKEE	2005	PDM (Passenger Door Module)																																														
GRAND CHEROKEE	2005	PTS (Park Assist Module)																																														
GRAND CHEROKEE	2005	RADIO (Radio)																																				V	V	V	V							
GRAND CHEROKEE	2005	SCM (Steering Column Module)																																														
GRAND CHEROKEE	2005	SDAR (Satellite Radio)																																														
GRAND CHEROKEE	2005	SUNR (Sunroof Module)																																														
GRAND CHEROKEE	2005	TCM (Transmission Control Module)																																														
GRAND CHEROKEE	2005	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
GRAND CHEROKEE	2005	WCM(Wireless Control Modules)														V																											V	V				
LIBERTY	2015	PCM (Powertrain Control Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
LIBERTY	2015	ABS (Anti Lock Brake System)																																													
LIBERTY	2015	AMP (Audio)																																													
LIBERTY	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																													
LIBERTY	2015	CGW (Central Gateway)																																													
LIBERTY	2015	ESM (Electronic Shifter Module)																																													
LIBERTY	2015	FDCM/AWD (Final Drive Control / All Wheel Drive)																																													
LIBERTY	2015	HFM (Hands Free Module)																																													
LIBERTY	2015	HVAC (Heat Vent A/C)																																													
LIBERTY	2015	ITM (Intrusion)																																													
LIBERTY	2015	MSMD (Memory Seet Module)																																													
LIBERTY	2015	OCM (Occupant Classification Module)																																													
LIBERTY	2015	ORC (Occupant Restraint Control)																																													
LIBERTY	2015	PTS (Park Assist Module)																																													
LIBERTY	2015	RADIO (Radio)																																													
LIBERTY	2015	RFH (Radio Frequency Hub)																																													
LIBERTY	2015	SAS (Steering Angle Sensor)																																													
LIBERTY	2015	SUNR (Sunroof Module)																																													
LIBERTY	2015	TCM (Transmission Control Module)																																													
LIBERTY	2015	WCM(Wireless Control Modules)																																													
LIBERTY	2014	PCM (Powertrain Control Module)																																													
LIBERTY	2014	ABS (Anti Lock Brake System)	V																																												
LIBERTY	2014	AMP (Audio)																						V	V																						
LIBERTY	2014	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
LIBERTY	2014	ESM (Electronic Shifter Module)																																													
LIBERTY	2014	HFM (Hands Free Module)																																								V					
LIBERTY	2014	HVAC (Heat Vent A/C)																								V	V	V	V																		
LIBERTY	2014	ITM (Intrusion)																																													
LIBERTY	2014	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V										
LIBERTY	2014	OCM (Occupant Classification Module)																																													
LIBERTY	2014	ORC (Occupant Restraint Control)		V																																											
LIBERTY	2014	PTS (Park Assist Module)																																													
LIBERTY	2014	RADIO (Radio)																																				V	V	V	V						
LIBERTY	2014	SAS (Steering Angle Sensor)																																													
LIBERTY	2014	SUNR (Sunroof Module)																																													
LIBERTY	2014	TCM (Transmission Control Module)																																													
LIBERTY	2014	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
LIBERTY	2014	WCM(Wireless Control Modules)														V																											V	V			
LIBERTY	2013	PCM (Powertrain Control Module)																																													
LIBERTY	2013	ABS (Anti Lock Brake System)	V																																												
LIBERTY	2013	AMP (Audio)																						V	V																						
LIBERTY	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
LIBERTY	2013	ESM (Electronic Shifter Module)																																													
LIBERTY	2013	HFM (Hands Free Module)																																								V					

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
LIBERTY	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
LIBERTY	2013	ITM (Intrusion)																																														
LIBERTY	2013	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
LIBERTY	2013	OCM (Occupant Classification Module)																																														
LIBERTY	2013	ORC (Occupant Restraint Control)		V																																												
LIBERTY	2013	PTS (Park Assist Module)																																														
LIBERTY	2013	RADIO (Radio)																																				V	V	V	V							
LIBERTY	2013	SAS (Steering Angle Sensor)																																														
LIBERTY	2013	SUNR (Sunroof Module)																																														
LIBERTY	2013	TCM (Transmission Control Module)																																														
LIBERTY	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
LIBERTY	2013	WCM(Wireless Control Modules)														V																											V	V				
LIBERTY	2012	PCM (Powertrain Control Module)																																														
LIBERTY	2012	ABS (Anti Lock Brake System)	V																																													
LIBERTY	2012	AMP (Audio)																						V	V																							
LIBERTY	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
LIBERTY	2012	ESM (Electronic Shifter Module)																																														
LIBERTY	2012	HFM (Hands Free Module)																																								V						
LIBERTY	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
LIBERTY	2012	ITM (Intrusion)																																														
LIBERTY	2012	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
LIBERTY	2012	OCM (Occupant Classification Module)																																														
LIBERTY	2012	ORC (Occupant Restraint Control)		V																																												
LIBERTY	2012	PTS (Park Assist Module)																																														
LIBERTY	2012	RADIO (Radio)																																				V	V	V	V							
LIBERTY	2012	SAS (Steering Angle Sensor)																																														
LIBERTY	2012	SUNR (Sunroof Module)																																														
LIBERTY	2012	TCM (Transmission Control Module)																																														
LIBERTY	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
LIBERTY	2012	WCM(Wireless Control Modules)														V																											V	V				
LIBERTY	2011	PCM (Powertrain Control Module)																																														
LIBERTY	2011	ABS (Anti Lock Brake System)	V																																													
LIBERTY	2011	AMP (Audio)																						V	V																							
LIBERTY	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
LIBERTY	2011	ESM (Electronic Shifter Module)																																														
LIBERTY	2011	HFM (Hands Free Module)																																								V						
LIBERTY	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
LIBERTY	2011	ITM (Intrusion)																																														
LIBERTY	2011	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
LIBERTY	2011	OCM (Occupant Classification Module)																																														
LIBERTY	2011	ORC (Occupant Restraint Control)		V																																												
LIBERTY	2011	PTS (Park Assist Module)																																														
LIBERTY	2011	RADIO (Radio)																																				V	V	V	V							

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
LIBERTY	2011	SAS (Steering Angle Sensor)																																														
LIBERTY	2011	SUNR (Sunroof Module)																																														
LIBERTY	2011	TCM (Transmission Control Module)																																														
LIBERTY	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
LIBERTY	2011	WCM(Wireless Control Modules)														V																											V	V			
LIBERTY	2010	PCM (Powertrain Control Module)																																														
LIBERTY	2010	ABS (Anti Lock Brake System)	V																																													
LIBERTY	2010	AMP (Audio)																						V	V																							
LIBERTY	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
LIBERTY	2010	ESM (Electronic Shifter Module)																																														
LIBERTY	2010	HFM (Hands Free Module)																																								V						
LIBERTY	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
LIBERTY	2010	ITM (Intrusion)																																														
LIBERTY	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
LIBERTY	2010	OCM (Occupant Classification Module)																																														
LIBERTY	2010	ORC (Occupant Restraint Control)		V																																												
LIBERTY	2010	PTS (Park Assist Module)																																														
LIBERTY	2010	RADIO (Radio)																																				V	V	V	V							
LIBERTY	2010	SAS (Steering Angle Sensor)																																														
LIBERTY	2010	SUNR (Sunroof Module)																																														
LIBERTY	2010	TCM (Transmission Control Module)																																														
LIBERTY	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
LIBERTY	2010	WCM(Wireless Control Modules)														V																											V	V			
LIBERTY	2009	PCM (Powertrain Control Module)																																														
LIBERTY	2009	ABS (Anti Lock Brake System)	V																																													
LIBERTY	2009	AMP (Audio)																						V	V																							
LIBERTY	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
LIBERTY	2009	ESM (Electronic Shifter Module)																																														
LIBERTY	2009	HFM (Hands Free Module)																																								V						
LIBERTY	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
LIBERTY	2009	ITM (Intrusion)																																														
LIBERTY	2009	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
LIBERTY	2009	OCM (Occupant Classification Module)																																														
LIBERTY	2009	ORC (Occupant Restraint Control)		V																																												
LIBERTY	2009	PTS (Park Assist Module)																																														
LIBERTY	2009	RADIO (Radio)																																				V	V	V	V							
LIBERTY	2009	SAS (Steering Angle Sensor)																																														
LIBERTY	2009	SUNR (Sunroof Module)																																														
LIBERTY	2009	TCM (Transmission Control Module)																																														
LIBERTY	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
LIBERTY	2009	VES3 (Vidio Entertainment System 3)																																														
LIBERTY	2009	WCM(Wireless Control Modules)														V																											V	V			
LIBERTY	2008	PCM (Powertrain Control Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
LIBERTY	2008	ABS (Anti Lock Brake System)	V																																													
LIBERTY	2008	AMP (Audio)																						V	V																							
LIBERTY	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
LIBERTY	2008	ESM (Electronic Shifter Module)																																														
LIBERTY	2008	HFM (Hands Free Module)																																								V						
LIBERTY	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
LIBERTY	2008	ITM (Intrusion)																																														
LIBERTY	2008	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
LIBERTY	2008	OCM (Occupant Classification Module)																																														
LIBERTY	2008	ORC (Occupant Restraint Control)		V																																												
LIBERTY	2008	PTS (Park Assist Module)																																														
LIBERTY	2008	RADIO (Radio)																																				V	V	V	V							
LIBERTY	2008	SAS (Steering Angle Sensor)																																														
LIBERTY	2008	SUNR (Sunroof Module)																																														
LIBERTY	2008	TCM (Transmission Control Module)																																														
LIBERTY	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
LIBERTY	2008	VES3 (Vidio Entertainment System 3)																																														
LIBERTY	2008	WCM(Wireless Control Modules)														V																											V	V				
LIBERTY	2007	PCM (Powertrain Control Module)																																														
LIBERTY	2007	ABS (Anti Lock Brake System)	V																																													
LIBERTY	2007	SAS (Steering Angle Sensor)																																														
LIBERTY	2006	PCM (Powertrain Control Module)																																														
LIBERTY	2006	ABS (Anti Lock Brake System)	V																																													
LIBERTY	2006	SAS (Steering Angle Sensor)																																														
LIBERTY	2006	TCM (Transmission Control Module)																																														
RAIDER	2010	PCM (Powertrain Control Module)																																														
RAIDER	2010	ABS (Anti Lock Brake System)	V																																													
RAIDER	2010	AMP (Audio)																						V	V																							
RAIDER	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAIDER	2010	EOM (Electric Overhead Module)																																											V			
RAIDER	2010	HFM (Hands Free Module)																																								V						
RAIDER	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
RAIDER	2010	ORC (Occupant Restraint Control)		V																																												
RAIDER	2010	RADIO (Radio)																																				V	V	V	V							
RAIDER	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
RAIDER	2010	WCM(Wireless Control Modules)														V																											V	V				
RAIDER	2009	PCM (Powertrain Control Module)																																														
RAIDER	2009	ABS (Anti Lock Brake System)	V																																													
RAIDER	2009	AMP (Audio)																						V	V																							
RAIDER	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
RAIDER	2009	EOM (Electric Overhead Module)																																											V			
RAIDER	2009	HFM (Hands Free Module)																																								V						
RAIDER	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RAIDER	2009	ORC (Occupant Restraint Control)		V																																												
RAIDER	2009	RADIO (Radio)																																				V	V	V	V						
RAIDER	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
RAIDER	2009	WCM(Wireless Control Modules)														V																											V	V			
RAIDER	2008	PCM (Powertrain Control Module)																																													
RAIDER	2008	ABS (Anti Lock Brake System)	V																																												
RAIDER	2008	AMP (Audio)																						V	V																						
RAIDER	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
RAIDER	2008	EOM (Electric Overhead Module)																																											V		
RAIDER	2008	HFM (Hands Free Module)																																							V						
RAIDER	2008	HVAC (Heat Vent A/C)																								V	V	V	V																		
RAIDER	2008	ORC (Occupant Restraint Control)		V																																											
RAIDER	2008	RADIO (Radio)																																				V	V	V	V						
RAIDER	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
RAIDER	2008	WCM(Wireless Control Modules)														V																											V	V			
RAIDER	2007	PCM (Powertrain Control Module)																																													
RAIDER	2007	ABS (Anti Lock Brake System)	V																																												
RAIDER	2007	AMP (Audio)																						V	V																						
RAIDER	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
RAIDER	2007	EOM (Electric Overhead Module)																																											V		
RAIDER	2007	HVAC (Heat Vent A/C)																								V	V	V	V																		
RAIDER	2007	OCM (Occupant Classification Module)																																													
RAIDER	2007	ORC (Occupant Restraint Control)		V																																											
RAIDER	2007	RADIO (Radio)																																				V	V	V	V						
RAIDER	2007	SDAR (Satellite Radio)																																													
RAIDER	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
RAIDER	2007	WCM(Wireless Control Modules)														V																											V	V			
RAIDER	2006	PCM (Powertrain Control Module)																																													
RAIDER	2006	ABS (Anti Lock Brake System)	V																																												
RAIDER	2006	AMP (Audio)																						V	V																						
RAIDER	2006	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
RAIDER	2006	EOM (Electric Overhead Module)																																											V		
RAIDER	2006	HFM (Hands Free Module)																																							V						
RAIDER	2006	HVAC (Heat Vent A/C)																								V	V	V	V																		
RAIDER	2006	OCM (Occupant Classification Module)																																													
RAIDER	2006	ORC (Occupant Restraint Control)		V																																											
RAIDER	2006	RADIO (Radio)																																				V	V	V	V						
RAIDER	2006	SDAR (Satellite Radio)																																													
RAIDER	2006	TCM (Transmission Control Module)																																													
RAIDER	2006	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
RAIDER	2006	WCM(Wireless Control Modules)														V																											V	V			
COMMANDER	2010	PCM (Powertrain Control Module)																																													
COMMANDER	2010	ABS (Anti Lock Brake System)	V																																												

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
COMMANDER	2010	AHBM (Automatic High Beam)																																														
COMMANDER	2010	AMP (Audio)																						V	V																							
COMMANDER	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
COMMANDER	2010	DDM (Drivers Door Module)																					V																									
COMMANDER	2010	ESM (Electronic Shifter Module)																																														
COMMANDER	2010	HFM (Hands Free Module)																																								V						
COMMANDER	2010	HSM (Heated Seat Module)																																														
COMMANDER	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
COMMANDER	2010	ITM (Intrusion)																																														
COMMANDER	2010	LRSM (Light Rain Sensor Module)																																														
COMMANDER	2010	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
COMMANDER	2010	ORC (Occupant Restraint Control)		V																																												
COMMANDER	2010	PDM (Passenger Door Module)																																														
COMMANDER	2010	PLM (Power Liftgate Module)																																														
COMMANDER	2010	PTS (Park Assist Module)																																														
COMMANDER	2010	RADIO (Radio)																																				V	V	V	V							
COMMANDER	2010	SAS (Steering Angle Sensor)																																														
COMMANDER	2010	SUNR (Sunroof Module)																																														
COMMANDER	2010	TCM (Transmission Control Module)																																														
COMMANDER	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
COMMANDER	2010	VES3 (Vidio Entertainment System 3)																																														
COMMANDER	2010	WCM(Wireless Control Modules)														V																											V	V				
COMMANDER	2009	PCM (Powertrain Control Module)																																														
COMMANDER	2009	ABS (Anti Lock Brake System)	V																																													
COMMANDER	2009	AHBM (Automatic High Beam)																																														
COMMANDER	2009	AMP (Audio)																						V	V																							
COMMANDER	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
COMMANDER	2009	DDM (Drivers Door Module)																					V																									
COMMANDER	2009	ESM (Electronic Shifter Module)																																														
COMMANDER	2009	HFM (Hands Free Module)																																								V						
COMMANDER	2009	HSM (Heated Seat Module)																																														
COMMANDER	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
COMMANDER	2009	ITM (Intrusion)																																														
COMMANDER	2009	LRSM (Light Rain Sensor Module)																																														
COMMANDER	2009	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
COMMANDER	2009	ORC (Occupant Restraint Control)		V																																												
COMMANDER	2009	PDM (Passenger Door Module)																																														
COMMANDER	2009	PLM (Power Liftgate Module)																																														
COMMANDER	2009	PTS (Park Assist Module)																																														
COMMANDER	2009	RADIO (Radio)																																				V	V	V	V							
COMMANDER	2009	SAS (Steering Angle Sensor)																																														
COMMANDER	2009	SUNR (Sunroof Module)																																														
COMMANDER	2009	TCM (Transmission Control Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
COMMANDER	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
COMMANDER	2009	VES3 (Vidio Entertainment System 3)																																														
COMMANDER	2009	WCM(Wireless Control Modules)														V																											V	V			
COMMANDER	2008	PCM (Powertrain Control Module)																																														
COMMANDER	2008	ABS (Anti Lock Brake System)	V																																													
COMMANDER	2008	AHBM (Automatic High Beam)																																														
COMMANDER	2008	AMP (Audio)																						V	V																							
COMMANDER	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
COMMANDER	2008	DDM (Drivers Door Module)																					V																									
COMMANDER	2008	ESM (Electronic Shifter Module)																																														
COMMANDER	2008	HFM (Hands Free Module)																																								V						
COMMANDER	2008	HSM (Heated Seat Module)																																														
COMMANDER	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
COMMANDER	2008	ITM (Intrusion)																																														
COMMANDER	2008	LRSM (Light Rain Sensor Module)																																														
COMMANDER	2008	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
COMMANDER	2008	ORC (Occupant Restraint Control)		V																																												
COMMANDER	2008	PDM (Passenger Door Module)																																														
COMMANDER	2008	PLM (Power Liftgate Module)																																														
COMMANDER	2008	PTS (Park Assist Module)																																														
COMMANDER	2008	RADIO (Radio)																																					V	V	V	V						
COMMANDER	2008	SAS (Steering Angle Sensor)																																														
COMMANDER	2008	SUNR (Sunroof Module)																																														
COMMANDER	2008	TCM (Transmission Control Module)																																														
COMMANDER	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
COMMANDER	2008	VES3 (Vidio Entertainment System 3)																																														
COMMANDER	2008	WCM(Wireless Control Modules)														V																											V	V			
COMMANDER	2007	PCM (Powertrain Control Module)																																														
COMMANDER	2007	ABS (Anti Lock Brake System)	V																																													
COMMANDER	2007	AHBM (Automatic High Beam)																																														
COMMANDER	2007	AMP (Audio)																						V	V																							
COMMANDER	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
COMMANDER	2007	DDM (Drivers Door Module)																					V																									
COMMANDER	2007	ESM (Electronic Shifter Module)																																														
COMMANDER	2007	HFM (Hands Free Module)																																								V						
COMMANDER	2007	HSM (Heated Seat Module)																																														
COMMANDER	2007	HVAC (Heat Vent A/C)																								V	V	V	V																			
COMMANDER	2007	ITM (Intrusion)																																														
COMMANDER	2007	LRSM (Light Rain Sensor Module)																																														
COMMANDER	2007	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
COMMANDER	2007	OCM (Occupant Classification Module)																																														
COMMANDER	2007	ORC (Occupant Restraint Control)		V																																												
COMMANDER	2007	PDM (Passenger Door Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
COMMANDER	2007	PTS (Park Assist Module)																																														
COMMANDER	2007	RADIO (Radio)																																				V	V	V	V						
COMMANDER	2007	SCM (Steering Column Module)																																														
COMMANDER	2007	SDAR (Satellite Radio)																																														
COMMANDER	2007	SUNR (Sunroof Module)																																														
COMMANDER	2007	TCM (Transmission Control Module)																																														
COMMANDER	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
COMMANDER	2007	WCM(Wireless Control Modules)														V																												V	V			
COMMANDER	2006	PCM (Powertrain Control Module)																																														
COMMANDER	2006	ABS (Anti Lock Brake System)	V																																													
COMMANDER	2006	AHBM (Automatic High Beam)																																														
COMMANDER	2006	AMP (Audio)																						V	V																							
COMMANDER	2006	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
COMMANDER	2006	DDM (Drivers Door Module)																					V																									
COMMANDER	2006	ESM (Electronic Shifter Module)																																														
COMMANDER	2006	HFM (Hands Free Module)																																								V						
COMMANDER	2006	HSM (Heated Seat Module)																																														
COMMANDER	2006	HVAC (Heat Vent A/C)																								V	V	V	V																			
COMMANDER	2006	ITM (Intrusion)																																														
COMMANDER	2006	LRSM (Light Rain Sensor Module)																																														
COMMANDER	2006	MSMD (Memory Seet Module)																												V	V	V	V	V	V	V	V											
COMMANDER	2006	OCM (Occupant Classification Module)																																														
COMMANDER	2006	ORC (Occupant Restraint Control)		V																																												
COMMANDER	2006	PDM (Passenger Door Module)																																														
COMMANDER	2006	PTS (Park Assist Module)																																														
COMMANDER	2006	RADIO (Radio)																																				V	V	V	V						
COMMANDER	2006	SCM (Steering Column Module)																																														
COMMANDER	2006	SDAR (Satellite Radio)																																														
COMMANDER	2006	SUNR (Sunroof Module)																																														
COMMANDER	2006	TCM (Transmission Control Module)																																														
COMMANDER	2006	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
COMMANDER	2006	WCM(Wireless Control Modules)														V																												V	V			
WRANGLER	2016	PCM (Powertrain Control Module)																																														
WRANGLER	2016	ABS (Anti Lock Brake System)																																														
WRANGLER	2016	AMP (Audio)																																														
WRANGLER	2016	BCM (Body Control Module)																																														
WRANGLER	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
WRANGLER	2016	CGW (Central Gateway)																																														
WRANGLER	2016	ESM (Electronic Shifter Module)																																														
WRANGLER	2016	HFM (Hands Free Module)																																														
WRANGLER	2016	HVAC (Heat Vent A/C)																																														
WRANGLER	2016	ITM (Intrusion)																																														
WRANGLER	2016	ORC (Occupant Restraint Control)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
WRANGLER	2016	RADIO (Radio)																																														
WRANGLER	2016	RFH (Radio Frequency Hub)																																														
WRANGLER	2016	SAS (Steering Angle Sensor)																																														
WRANGLER	2016	TCM (Transmission Control Module)																																														
WRANGLER	2016	TPM (Tire Pressure Monitor)																																														
WRANGLER	2016	WCM(Wireless Control Modules)																																														
WRANGLER	2015	PCM (Powertrain Control Module)																																														
WRANGLER	2015	ABS (Anti Lock Brake System)																																														
WRANGLER	2015	AMP (Audio)																																														
WRANGLER	2015	BCM (Body Control Module)																																														
WRANGLER	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
WRANGLER	2015	CGW (Central Gateway)																																														
WRANGLER	2015	ESM (Electronic Shifter Module)																																														
WRANGLER	2015	HFM (Hands Free Module)																																														
WRANGLER	2015	HVAC (Heat Vent A/C)																																														
WRANGLER	2015	ITM (Intrusion)																																														
WRANGLER	2015	ORC (Occupant Restraint Control)																																														
WRANGLER	2015	RADIO (Radio)																																														
WRANGLER	2015	RFH (Radio Frequency Hub)																																														
WRANGLER	2015	SAS (Steering Angle Sensor)																																														
WRANGLER	2015	TCM (Transmission Control Module)																																														
WRANGLER	2015	TPM (Tire Pressure Monitor)																																														
WRANGLER	2015	WCM(Wireless Control Modules)																																														
WRANGLER	2014	PCM (Powertrain Control Module)																																														
WRANGLER	2014	ABS (Anti Lock Brake System)	V																																													
WRANGLER	2014	AMP (Audio)																						V	V																							
WRANGLER	2014	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
WRANGLER	2014	ESM (Electronic Shifter Module)																																														
WRANGLER	2014	HFM (Hands Free Module)																																								V						
WRANGLER	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
WRANGLER	2014	ITM (Intrusion)																																														
WRANGLER	2014	ORC (Occupant Restraint Control)		V																																												
WRANGLER	2014	RADIO (Radio)																																				V	V	V	V							
WRANGLER	2014	SAS (Steering Angle Sensor)																																														
WRANGLER	2014	TCM (Transmission Control Module)																																														
WRANGLER	2014	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
WRANGLER	2014	TPM (Tire Pressure Monitor)																																														
WRANGLER	2014	WCM(Wireless Control Modules)														V																											V	V				
WRANGLER	2013	PCM (Powertrain Control Module)																																														
WRANGLER	2013	ABS (Anti Lock Brake System)	V																																													
WRANGLER	2013	AMP (Audio)																						V	V																							
WRANGLER	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
WRANGLER	2013	ESM (Electronic Shifter Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
WRANGLER	2013	HFM (Hands Free Module)																																								V						
WRANGLER	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
WRANGLER	2013	ITM (Intrusion)																																														
WRANGLER	2013	ORC (Occupant Restraint Control)		V																																												
WRANGLER	2013	RADIO (Radio)																																				V	V	V	V							
WRANGLER	2013	SAS (Steering Angle Sensor)																																														
WRANGLER	2013	TCM (Transmission Control Module)																																														
WRANGLER	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
WRANGLER	2013	TPM (Tire Pressure Monitor)																																														
WRANGLER	2013	WCM(Wireless Control Modules)														V																				V							V	V				
WRANGLER	2012	PCM (Powertrain Control Module)																																														
WRANGLER	2012	ABS (Anti Lock Brake System)	V																																													
WRANGLER	2012	AMP (Audio)																						V	V																							
WRANGLER	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
WRANGLER	2012	ESM (Electronic Shifter Module)																																														
WRANGLER	2012	HFM (Hands Free Module)																																								V						
WRANGLER	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
WRANGLER	2012	ITM (Intrusion)																																														
WRANGLER	2012	ORC (Occupant Restraint Control)		V																																												
WRANGLER	2012	RADIO (Radio)																																				V	V	V	V							
WRANGLER	2012	SAS (Steering Angle Sensor)																																														
WRANGLER	2012	TCM (Transmission Control Module)																																														
WRANGLER	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
WRANGLER	2012	WCM(Wireless Control Modules)														V																											V	V				
WRANGLER	2011	PCM (Powertrain Control Module)																																														
WRANGLER	2011	ABS (Anti Lock Brake System)	V																																													
WRANGLER	2011	AMP (Audio)																						V	V																							
WRANGLER	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
WRANGLER	2011	ESM (Electronic Shifter Module)																																														
WRANGLER	2011	HFM (Hands Free Module)																																								V						
WRANGLER	2011	HVAC (Heat Vent A/C)																								V	V	V	V																			
WRANGLER	2011	ITM (Intrusion)																																														
WRANGLER	2011	ORC (Occupant Restraint Control)		V																																												
WRANGLER	2011	RADIO (Radio)																																				V	V	V	V							
WRANGLER	2011	SAS (Steering Angle Sensor)																																														
WRANGLER	2011	TCM (Transmission Control Module)																																														
WRANGLER	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
WRANGLER	2011	WCM(Wireless Control Modules)														V																											V	V				
WRANGLER	2010	PCM (Powertrain Control Module)																																														
WRANGLER	2010	ABS (Anti Lock Brake System)	V																																													
WRANGLER	2010	AMP (Audio)																						V	V																							
WRANGLER	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
WRANGLER	2010	HFM (Hands Free Module)																																								V						

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
WRANGLER	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
WRANGLER	2010	ITM (Intrusion)																																														
WRANGLER	2010	ORC (Occupant Restraint Control)		V																																												
WRANGLER	2010	RADIO (Radio)																																				V	V	V	V							
WRANGLER	2010	SAS (Steering Angle Sensor)																																														
WRANGLER	2010	TCM (Transmission Control Module)																																														
WRANGLER	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
WRANGLER	2010	WCM(Wireless Control Modules)														V																											V	V				
WRANGLER	2009	PCM (Powertrain Control Module)																																														
WRANGLER	2009	ABS (Anti Lock Brake System)	V																																													
WRANGLER	2009	AMP (Audio)																						V	V																							
WRANGLER	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
WRANGLER	2009	HFM (Hands Free Module)																																								V						
WRANGLER	2009	HVAC (Heat Vent A/C)																								V	V	V	V																			
WRANGLER	2009	ITM (Intrusion)																																														
WRANGLER	2009	ORC (Occupant Restraint Control)		V																																												
WRANGLER	2009	RADIO (Radio)																																				V	V	V	V							
WRANGLER	2009	SAS (Steering Angle Sensor)																																														
WRANGLER	2009	TCM (Transmission Control Module)																																														
WRANGLER	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
WRANGLER	2009	WCM(Wireless Control Modules)														V																											V	V				
WRANGLER	2008	PCM (Powertrain Control Module)																																														
WRANGLER	2008	ABS (Anti Lock Brake System)	V																																													
WRANGLER	2008	AMP (Audio)																						V	V																							
WRANGLER	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
WRANGLER	2008	HVAC (Heat Vent A/C)																								V	V	V	V																			
WRANGLER	2008	ITM (Intrusion)																																														
WRANGLER	2008	ORC (Occupant Restraint Control)		V																																												
WRANGLER	2008	RADIO (Radio)																																				V	V	V	V							
WRANGLER	2008	SAS (Steering Angle Sensor)																																														
WRANGLER	2008	TCM (Transmission Control Module)																																														
WRANGLER	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																		
WRANGLER	2008	WCM(Wireless Control Modules)														V																											V	V				
WRANGLER	2007	PCM (Powertrain Control Module)																																														
WRANGLER	2007	ABS (Anti Lock Brake System)	V																																													
WRANGLER	2007	AMP (Audio)																						V	V																							
WRANGLER	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
WRANGLER	2007	HVAC (Heat Vent A/C)																								V	V	V	V																			
WRANGLER	2007	ITM (Intrusion)																																														
WRANGLER	2007	OCM (Occupant Classification Module)																																														
WRANGLER	2007	ORC (Occupant Restraint Control)		V																																												
WRANGLER	2007	RADIO (Radio)																																				V	V	V	V							
WRANGLER	2007	SAS (Steering Angle Sensor)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
WRANGLER	2007	TCM (Transmission Control Module)																																														
WRANGLER	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
WRANGLER	2007	WCM(Wireless Control Modules)														V																											V	V				
COMPASS	2016	PCM (Powertrain Control Module)																																														
COMPASS	2016	ABS (Anti Lock Brake System)																																														
COMPASS	2016	AMP (Audio)																																														
COMPASS	2016	BCM (Body Control Module)																																														
COMPASS	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
COMPASS	2016	CGW (Central Gateway)																																														
COMPASS	2016	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
COMPASS	2016	HFM (Hands Free Module)																																														
COMPASS	2016	HVAC (Heat Vent A/C)																																														
COMPASS	2016	ITM (Intrusion)																																														
COMPASS	2016	ORC (Occupant Restraint Control)																																														
COMPASS	2016	RADIO (Radio)																																														
COMPASS	2016	RFH (Radio Frequency Hub)																																														
COMPASS	2016	SAS (Steering Angle Sensor)																																														
COMPASS	2016	TCM (Transmission Control Module)																																														
COMPASS	2016	WCM(Wireless Control Modules)																																														
COMPASS	2015	PCM (Powertrain Control Module)																																														
COMPASS	2015	ABS (Anti Lock Brake System)																																														
COMPASS	2015	AMP (Audio)																																														
COMPASS	2015	BCM (Body Control Module)																																														
COMPASS	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
COMPASS	2015	CGW (Central Gateway)																																														
COMPASS	2015	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
COMPASS	2015	HFM (Hands Free Module)																																														
COMPASS	2015	HVAC (Heat Vent A/C)																																														
COMPASS	2015	ITM (Intrusion)																																														
COMPASS	2015	ORC (Occupant Restraint Control)																																														
COMPASS	2015	RADIO (Radio)																																														
COMPASS	2015	RFH (Radio Frequency Hub)																																														
COMPASS	2015	SAS (Steering Angle Sensor)																																														
COMPASS	2015	TCM (Transmission Control Module)																																														
COMPASS	2015	WCM(Wireless Control Modules)																																														
COMPASS	2014	PCM (Powertrain Control Module)																																														
COMPASS	2014	ABS (Anti Lock Brake System)	V																																													
COMPASS	2014	AMP (Audio)																						V	V																							
COMPASS	2014	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
COMPASS	2014	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
COMPASS	2014	HFM (Hands Free Module)																																								V						
COMPASS	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
COMPASS	2014	ITM (Intrusion)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
COMPASS	2014	ORC (Occupant Restraint Control)		V																																												
COMPASS	2014	RADIO (Radio)																																				V	V	V	V						
COMPASS	2014	SAS (Steering Angle Sensor)																																													
COMPASS	2014	TCM (Transmission Control Module)																																													
COMPASS	2014	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
COMPASS	2014	WCM(Wireless Control Modules)														V																											V	V			
COMPASS	2013	PCM (Powertrain Control Module)																																													
COMPASS	2013	ABS (Anti Lock Brake System)	V																																												
COMPASS	2013	AMP (Audio)																						V	V																						
COMPASS	2013	FDCM/AWD (Final Drive Control / All Wheel Drive)																																													
COMPASS	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
COMPASS	2013	HFM (Hands Free Module)																																								V					
COMPASS	2013	HVAC (Heat Vent A/C)																								V	V	V	V																		
COMPASS	2013	ITM (Intrusion)																																													
COMPASS	2013	ORC (Occupant Restraint Control)		V																																											
COMPASS	2013	RADIO (Radio)																																				V	V	V	V						
COMPASS	2013	SAS (Steering Angle Sensor)																																													
COMPASS	2013	TCM (Transmission Control Module)																																													
COMPASS	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
COMPASS	2013	WCM(Wireless Control Modules)														V																											V	V			
COMPASS	2012	PCM (Powertrain Control Module)																																													
COMPASS	2012	ABS (Anti Lock Brake System)	V																																												
COMPASS	2012	AMP (Audio)																						V	V																						
COMPASS	2012	FDCM/AWD (Final Drive Control / All Wheel Drive)																																													
COMPASS	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
COMPASS	2012	HFM (Hands Free Module)																																								V					
COMPASS	2012	HVAC (Heat Vent A/C)																								V	V	V	V																		
COMPASS	2012	ITM (Intrusion)																																													
COMPASS	2012	ORC (Occupant Restraint Control)		V																																											
COMPASS	2012	RADIO (Radio)																																				V	V	V	V						
COMPASS	2012	SAS (Steering Angle Sensor)																																													
COMPASS	2012	TCM (Transmission Control Module)																																													
COMPASS	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
COMPASS	2012	WCM(Wireless Control Modules)														V																											V	V			
COMPASS	2011	PCM (Powertrain Control Module)																																													
COMPASS	2011	ABS (Anti Lock Brake System)	V																																												
COMPASS	2011	AMP (Audio)																						V	V																						
COMPASS	2011	FDCM/AWD (Final Drive Control / All Wheel Drive)																																													
COMPASS	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
COMPASS	2011	HFM (Hands Free Module)																																								V					
COMPASS	2011	HVAC (Heat Vent A/C)																								V	V	V	V																		
COMPASS	2011	ITM (Intrusion)																																													
COMPASS	2011	ORC (Occupant Restraint Control)		V																																											

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
COMPASS	2011	RADIO (Radio)																																				V	V	V	V						
COMPASS	2011	SAS (Steering Angle Sensor)																																														
COMPASS	2011	TCM (Transmission Control Module)																																														
COMPASS	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
COMPASS	2011	WCM(Wireless Control Modules)														V																											V	V			
COMPASS	2010	PCM (Powertrain Control Module)																																														
COMPASS	2010	ABS (Anti Lock Brake System)	V																																													
COMPASS	2010	AMP (Audio)																						V	V																							
COMPASS	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
COMPASS	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
COMPASS	2010	HFM (Hands Free Module)																																								V						
COMPASS	2010	HVAC (Heat Vent A/C)																								V	V	V	V																			
COMPASS	2010	ITM (Intrusion)																																														
COMPASS	2010	ORC (Occupant Restraint Control)		V																																												
COMPASS	2010	RADIO (Radio)																																				V	V	V	V						
COMPASS	2010	SAS (Steering Angle Sensor)																																														
COMPASS	2010	TCM (Transmission Control Module)																																														
COMPASS	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
COMPASS	2010	WCM(Wireless Control Modules)														V																											V	V			
COMPASS	2009	PCM (Powertrain Control Module)																																														
COMPASS	2009	ABS (Anti Lock Brake System)	V																																													
COMPASS	2009	AMP (Audio)																						V	V																							
COMPASS	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
COMPASS	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
COMPASS	2009	HFM (Hands Free Module)																																								V						
COMPASS	2009	ITM (Intrusion)																																														
COMPASS	2009	ORC (Occupant Restraint Control)		V																																												
COMPASS	2009	RADIO (Radio)																																				V	V	V	V						
COMPASS	2009	SAS (Steering Angle Sensor)																																														
COMPASS	2009	TCM (Transmission Control Module)																																														
COMPASS	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
COMPASS	2009	WCM(Wireless Control Modules)														V																											V	V			
COMPASS	2008	PCM (Powertrain Control Module)																																														
COMPASS	2008	ABS (Anti Lock Brake System)	V																																													
COMPASS	2008	AMP (Audio)																						V	V																							
COMPASS	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
COMPASS	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
COMPASS	2008	HFM (Hands Free Module)																																								V						
COMPASS	2008	ITM (Intrusion)																																														
COMPASS	2008	ORC (Occupant Restraint Control)		V																																												
COMPASS	2008	RADIO (Radio)																																				V	V	V	V						
COMPASS	2008	SAS (Steering Angle Sensor)																																														
COMPASS	2008	SDAR (Satellite Radio)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
COMPASS	2008	TCM (Transmission Control Module)																																														
COMPASS	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
COMPASS	2008	WCM(Wireless Control Modules)														V																											V	V			
COMPASS	2007	PCM (Powertrain Control Module)																																														
COMPASS	2007	ABS (Anti Lock Brake System)	V																																													
COMPASS	2007	AMP (Audio)																						V	V																							
COMPASS	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
COMPASS	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
COMPASS	2007	HFM (Hands Free Module)																																								V						
COMPASS	2007	ITM (Intrusion)																																														
COMPASS	2007	OCM (Occupant Classification Module)																																														
COMPASS	2007	ORC (Occupant Restraint Control)		V																																												
COMPASS	2007	RADIO (Radio)																																				V	V	V	V							
COMPASS	2007	SAS (Steering Angle Sensor)																																														
COMPASS	2007	SDAR (Satellite Radio)																																														
COMPASS	2007	TCM (Transmission Control Module)																																														
COMPASS	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
COMPASS	2007	WCM(Wireless Control Modules)														V																											V	V			
PATRIOT	2016	PCM (Powertrain Control Module)																																														
PATRIOT	2016	ABS (Anti Lock Brake System)																																														
PATRIOT	2016	AMP (Audio)																																														
PATRIOT	2016	BCM (Body Control Module)																																														
PATRIOT	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
PATRIOT	2016	CGW (Central Gateway)																																														
PATRIOT	2016	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
PATRIOT	2016	HFM (Hands Free Module)																																														
PATRIOT	2016	HVAC (Heat Vent A/C)																																														
PATRIOT	2016	ITM (Intrusion)																																														
PATRIOT	2016	ORC (Occupant Restraint Control)																																														
PATRIOT	2016	RADIO (Radio)																																														
PATRIOT	2016	RFH (Radio Frequency Hub)																																														
PATRIOT	2016	SAS (Steering Angle Sensor)																																														
PATRIOT	2016	TCM (Transmission Control Module)																																														
PATRIOT	2016	WCM(Wireless Control Modules)																																														
PATRIOT	2015	PCM (Powertrain Control Module)																																														
PATRIOT	2015	ABS (Anti Lock Brake System)																																														
PATRIOT	2015	AMP (Audio)																																														
PATRIOT	2015	BCM (Body Control Module)																																														
PATRIOT	2015	CCN (Instrument Cluster / Cabin Compartment Node)																																														
PATRIOT	2015	CGW (Central Gateway)																																														
PATRIOT	2015	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
PATRIOT	2015	HFM (Hands Free Module)																																														
PATRIOT	2015	HVAC (Heat Vent A/C)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
PATRIOT	2015	ITM (Intrusion)																																														
PATRIOT	2015	ORC (Occupant Restraint Control)																																														
PATRIOT	2015	RADIO (Radio)																																														
PATRIOT	2015	RFH (Radio Frequency Hub)																																														
PATRIOT	2015	SAS (Steering Angle Sensor)																																														
PATRIOT	2015	TCM (Transmission Control Module)																																														
PATRIOT	2015	WCM(Wireless Control Modules)																																														
PATRIOT	2014	PCM (Powertrain Control Module)																																														
PATRIOT	2014	ABS (Anti Lock Brake System)	V																																													
PATRIOT	2014	AMP (Audio)																						V	V																							
PATRIOT	2014	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
PATRIOT	2014	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
PATRIOT	2014	HFM (Hands Free Module)																																								V						
PATRIOT	2014	HVAC (Heat Vent A/C)																								V	V	V	V																			
PATRIOT	2014	ITM (Intrusion)																																														
PATRIOT	2014	ORC (Occupant Restraint Control)		V																																												
PATRIOT	2014	RADIO (Radio)																																				V	V	V	V							
PATRIOT	2014	SAS (Steering Angle Sensor)																																														
PATRIOT	2014	TCM (Transmission Control Module)																																														
PATRIOT	2014	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
PATRIOT	2014	WCM(Wireless Control Modules)														V																											V	V				
PATRIOT	2013	PCM (Powertrain Control Module)																																														
PATRIOT	2013	ABS (Anti Lock Brake System)	V																																													
PATRIOT	2013	AMP (Audio)																						V	V																							
PATRIOT	2013	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
PATRIOT	2013	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
PATRIOT	2013	HFM (Hands Free Module)																																								V						
PATRIOT	2013	HVAC (Heat Vent A/C)																								V	V	V	V																			
PATRIOT	2013	ITM (Intrusion)																																														
PATRIOT	2013	ORC (Occupant Restraint Control)		V																																												
PATRIOT	2013	RADIO (Radio)																																				V	V	V	V							
PATRIOT	2013	SAS (Steering Angle Sensor)																																														
PATRIOT	2013	TCM (Transmission Control Module)																																														
PATRIOT	2013	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
PATRIOT	2013	WCM(Wireless Control Modules)														V																											V	V				
PATRIOT	2012	PCM (Powertrain Control Module)																																														
PATRIOT	2012	ABS (Anti Lock Brake System)	V																																													
PATRIOT	2012	AMP (Audio)																						V	V																							
PATRIOT	2012	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
PATRIOT	2012	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
PATRIOT	2012	HFM (Hands Free Module)																																								V						
PATRIOT	2012	HVAC (Heat Vent A/C)																								V	V	V	V																			
PATRIOT	2012	ITM (Intrusion)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
PATRIOT	2012	ORC (Occupant Restraint Control)		V																																												
PATRIOT	2012	RADIO (Radio)																																				V	V	V	V						
PATRIOT	2012	SAS (Steering Angle Sensor)																																													
PATRIOT	2012	TCM (Transmission Control Module)																																													
PATRIOT	2012	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
PATRIOT	2012	WCM(Wireless Control Modules)														V																											V	V			
PATRIOT	2011	PCM (Powertrain Control Module)																																													
PATRIOT	2011	ABS (Anti Lock Brake System)	V																																												
PATRIOT	2011	AMP (Audio)																						V	V																						
PATRIOT	2011	FDCM/AWD (Final Drive Control / All Wheel Drive)																																													
PATRIOT	2011	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
PATRIOT	2011	HFM (Hands Free Module)																																								V					
PATRIOT	2011	HVAC (Heat Vent A/C)																								V	V	V	V																		
PATRIOT	2011	ITM (Intrusion)																																													
PATRIOT	2011	ORC (Occupant Restraint Control)		V																																											
PATRIOT	2011	RADIO (Radio)																																				V	V	V	V						
PATRIOT	2011	SAS (Steering Angle Sensor)																																													
PATRIOT	2011	TCM (Transmission Control Module)																																													
PATRIOT	2011	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
PATRIOT	2011	WCM(Wireless Control Modules)														V																											V	V			
PATRIOT	2010	PCM (Powertrain Control Module)																																													
PATRIOT	2010	ABS (Anti Lock Brake System)	V																																												
PATRIOT	2010	AMP (Audio)																						V	V																						
PATRIOT	2010	FDCM/AWD (Final Drive Control / All Wheel Drive)																																													
PATRIOT	2010	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
PATRIOT	2010	HFM (Hands Free Module)																																								V					
PATRIOT	2010	HVAC (Heat Vent A/C)																								V	V	V	V																		
PATRIOT	2010	ITM (Intrusion)																																													
PATRIOT	2010	ORC (Occupant Restraint Control)		V																																											
PATRIOT	2010	RADIO (Radio)																																				V	V	V	V						
PATRIOT	2010	SAS (Steering Angle Sensor)																																													
PATRIOT	2010	TCM (Transmission Control Module)																																													
PATRIOT	2010	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																
PATRIOT	2010	WCM(Wireless Control Modules)														V																											V	V			
PATRIOT	2009	PCM (Powertrain Control Module)																																													
PATRIOT	2009	ABS (Anti Lock Brake System)	V																																												
PATRIOT	2009	AMP (Audio)																						V	V																						
PATRIOT	2009	FDCM/AWD (Final Drive Control / All Wheel Drive)																																													
PATRIOT	2009	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																									
PATRIOT	2009	HFM (Hands Free Module)																																								V					
PATRIOT	2009	ITM (Intrusion)																																													
PATRIOT	2009	ORC (Occupant Restraint Control)		V																																											
PATRIOT	2009	RADIO (Radio)																																				V	V	V	V						

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
PATRIOT	2009	SAS (Steering Angle Sensor)																																														
PATRIOT	2009	TCM (Transmission Control Module)																																														
PATRIOT	2009	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
PATRIOT	2009	WCM(Wireless Control Modules)														V																											V	V				
PATRIOT	2008	PCM (Powertrain Control Module)																																														
PATRIOT	2008	ABS (Anti Lock Brake System)	V																																													
PATRIOT	2008	AMP (Audio)																						V	V																							
PATRIOT	2008	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
PATRIOT	2008	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
PATRIOT	2008	HFM (Hands Free Module)																																								V						
PATRIOT	2008	ITM (Intrusion)																																														
PATRIOT	2008	ORC (Occupant Restraint Control)		V																																												
PATRIOT	2008	RADIO (Radio)																																				V	V	V	V							
PATRIOT	2008	SAS (Steering Angle Sensor)																																														
PATRIOT	2008	SDAR (Satellite Radio)																																														
PATRIOT	2008	TCM (Transmission Control Module)																																														
PATRIOT	2008	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
PATRIOT	2008	WCM(Wireless Control Modules)														V																											V	V				
PATRIOT	2007	PCM (Powertrain Control Module)																																														
PATRIOT	2007	ABS (Anti Lock Brake System)	V																																													
PATRIOT	2007	AMP (Audio)																						V	V																							
PATRIOT	2007	FDCM/AWD (Final Drive Control / All Wheel Drive)																																														
PATRIOT	2007	CCN (Instrument Cluster / Cabin Compartment Node)															V	V	V	V	V	V																										
PATRIOT	2007	HFM (Hands Free Module)																																								V						
PATRIOT	2007	ITM (Intrusion)																																														
PATRIOT	2007	OCM (Occupant Classification Module)																																														
PATRIOT	2007	ORC (Occupant Restraint Control)		V																																												
PATRIOT	2007	RADIO (Radio)																																				V	V	V	V							
PATRIOT	2007	SAS (Steering Angle Sensor)																																														
PATRIOT	2007	SDAR (Satellite Radio)																																														
PATRIOT	2007	TCM (Transmission Control Module)																																														
PATRIOT	2007	CGW (Central Gateway)			V	V	V	V	V	V	V	V	V	V	V																																	
PATRIOT	2007	WCM(Wireless Control Modules)														V																											V	V				
RENEGADE	2016	PCM (Powertrain Control Module)																																														
RENEGADE	2016	ABS (Anti Lock Brake System)																																														
RENEGADE	2016	ACC (Adaptive Cruise Control)																																														
RENEGADE	2016	AMP (Audio)																																														
RENEGADE	2016	BCM (Body Control Module)																																														
RENEGADE	2016	CCN (Instrument Cluster / Cabin Compartment Node)																																														
RENEGADE	2016	CGW (Central Gateway)																																														
RENEGADE	2016	DDM (Drivers Door Module)																																														
RENEGADE	2016	DTCM (Drive Train Control Module)																																														
RENEGADE	2016	EDM (Electronic Damper Module)																																														

Vehicle	Year	System	Cycle Stop Lamp Relay	Initialize ORC	Accessory Time Delay	Add Navigation Radio	Change Country Code	Disable Radio clock Display	Enable DRL	Flash Hazard Lamps On Lock	Headlamp Delay Time	Headlamps On With Wipers	FCM Horn Chirp Duration	Illuminated Entry Time	Sound Horn On Lock	Antenna Loop Test	Change Language Preference	Update Measurement Unit	Unlock Driver Door On 1st Press	Seatbelt Alert Minder	Auto Door Unlock	Auto Door Lock	Denormalize Window	AMP Input Test	AMP Software Test	Actuator Calibration Test	Front Blower State	Cool Down Test	HVAC Self Test	Drive All Motors	Easy Entry/Exit Feature	Key Fobs Linked To Memory Feature	Standardization Routine	Tilt Mirrors In Reverse Feature	Actuate Memory Seat and Pedals	Easy Entry/Exit	Self Test	Radio Tone Test	Radio Anti-Theft Override Test	Radio Hard-drive Back-up	Enable/Disable Front Seat Video	HFM Self Test	Erase All Ignition Keys	Program Ignition Keys or Key FOBs	Self Test	FFCM Calibration	Service Procedure
RENEGADE	2016	EPS (Electric Power Steering)																																													
RENEGADE	2016	ESM (Electronic Shifter Module)																																													
RENEGADE	2016	FFCM (Front Facing Camera Module)																																												V	
RENEGADE	2016	HVAC (Heat Vent A/C)																																													
RENEGADE	2016	ICS (Integrated Center Stack)																																													
RENEGADE	2016	IPC (Instrument Panel Cluster)																																													
RENEGADE	2016	LBSS (Left Blind Spot Sensor)																																													
RENEGADE	2016	MSMD (Memory Seet Module)																																													
RENEGADE	2016	OCM (Occupant Classification Module)																																													
RENEGADE	2016	ORC (Occupant Restraint Control)																																													
RENEGADE	2016	PDM (Passenger Door Module)																																													
RENEGADE	2016	PLM (Power Liftgate Module)																																													
RENEGADE	2016	RADIO (Radio)																																													
RENEGADE	2016	RBSS (Right Blind Spot Sensor)																																													
RENEGADE	2016	RFH (Radio Frequency Hub)																																													
RENEGADE	2016	SCM (Steering Column Module)																																													
RENEGADE	2016	TCM (Transmission Control Module)																																													
RENEGADE	2016	WCM(Wireless Control Modules)																																													

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Regeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
Defender	2011	PCM (Powertrain Control Module)		V				V																			
		ABS (ABS Control Module)		V																							
		IPC (Instrument Cluster Control Module)		V																							
	2012~2015	PCM (Powertrain Control Module)		V																							
		ABS (ABS Control Module)		V																							
		IPC (Instrument Cluster Control Module)		V																							
Discovery 3 (LR3)	2005~2009	PCM (Powertrain Control Module)	406PN - V6 4.0 Petrol	V		V		V																			
			276DT - V6 2.7 DIESEL non cDPF	V				V																			
			276DT - V6 2.7 DIESEL with cDPF	V				V																			
			448PN - AJ V8 4.4 Petrol	V				V																			
		TCM (Transmission Control Module)		V		V																					
		TCCM (Transfer Case Control Module)		V		V																					
		VDM (Vehicle dynamics module (ABS))		V		V																V					
		RCM (Restraints Control Module)		V		V																					
		SASM (Steering Angle Sensor Module)		V		V																					
		ATCM (All Terrain Control Module)		V		V																					
		CCM (Adaptive Speed Control Control Module)		V																							
		FLM (Front Lighting Control Module)		V		V																					
		IPC (Instrument Cluster Control Module)		V		V			V	V																	
		PBM (Parking Brake Control Module)		V		V																		V	V	V	V
		RDCM (Rear Differential Control Module)		V		V																					
		RLM (Ride Level Control Module)		V		V																					
		ACM (Audio Front Control Module)		V																							
		BCM (Body Control Module)		V																							
		HVAC (Heating Ventilation and Air Conditioning Control Module)		V																							
		PAM (Parking Assist Control Module)		V																							
		TPM (Tyre Pressure Monitoring System)		V																							
		TEL (Cell Phone Module)	69	V																							
		TMC (Traffic Message Control Module)	70	V																							
		PCM (Powertrain Control Module)		V				V									V				V						
		TCM (Transmission Control Module)		V																							
		TCCM (Transfer Case Control Module)		V																							
		ABS (ABS Control Module)		V																							
		RCM (Restraints Control Module)		V																							
		SASM (Steering Angle Sensor Module)		V																							
		VIM (Vehicle Immobiliser Module)		V																							

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Regeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
Discovery 4 (LR4)	2010~2011	ATCM (All Terrain Control Module)		V																							
		BCM (Body Control Module)		V																							
		CCM (Adaptive Speed Control Control Module)		V																							
		HCM (Headlamp Control Module)		V																							
		IPC (Instrument Cluster Control Module)		V																							
		OCS (Restraints Occupancy System)		V																							
		PBM (Parking Brake Control Module)		V																							
		RDCM (Rear Differential Control Module)		V																							
		RLM (Ride Level Control Module)		V																							
		AHCM (Auxiliary Heater Control Module)		V																							
		APIM (Accessory Protocol Interface Module)		V																							
		DDM (Driver's Door Module)		V																							
		DSM (Driver's Seat Module)		V																							
		HCMB (Headlamp Control Module B)		V																							
		HVAC (Heating Ventilation and Air Conditioning Control Module)		V																							
		KVM (Keyless Vehicle Module)		V																							
		PAM (Parking Assist Control Module)		V																							
		PDM (Passenger's Door Module)		V																							
		FCDIM (Front Control/Display Interface Module)	56	V																							
		FCIM (Front Controls Interface Module)	57	V																							
		FCIMB (Front Controls Interface Module B)	58	V																							
		IPMB (Image Processing Module B)	63	V																							
		TEL (Cell Phone Module)	69	V																							
		PCM (Powertrain Control Module)	508PN - V8 5.0 Petrol	V				V																			
			508PN - V8 5.0 NA Petrol	V				V																			
			276DT - V6 2.7 Diesel non cDPF	V				V																			
			306DT - V6 3.0 Hi Pwr Diesel non cDP	V				V																			
			306DT - V6 3.0 Hi Pwr Diesel with cDP	V				V																			
			306DT - V6 3.0 Lo Pwr Diesel with cDP	V				V																			
		TCM (Transmission Control Module)		V																							
		TCCM (Transfer Case Control Module)		V																							
		GSM (Gear Shift Module)		V																							
		ABS (ABS Control Module)		V																							
		RCM (Restraints Control Module)		V																							
		SASM (Steering Angle Sensor Module)		V																							
		VIM (Vehicle Immobiliser Module)		V																							

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Regeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
Discovery 4 (LR4)	2012~2013	ATCM (All Terrain Control Module)		V																							
		BCM (Body Control Module)		V																							
		HCM (Headlamp Control Module)		V																							
		IPC (Instrument Cluster Control Module)		V																							
		OCS (Restraints Occupancy System)		V																							
		PBM (Parking Brake Control Module)		V																							
		RLM (Ride Level Control Module)		V																							
		RDCM (Rear Differential Control Module)		V																							
		AHCM (Auxiliary Heater Control Module)		V																							
		AHU (Audio Head Unit)		V																							
		DDM (Driver's Door Module)		V																							
		DSM (Driver's Seat Module)		V																							
		HVAC (Heating Ventilation and Air Conditioning Control Module)		V																							
		KVM (Keyless Vehicle Module)		V																							
		PAM (Parking Assist Control Module)		V																							
		PDM (Passenger's Door Module)		V																							
		HCMB (Headlamp Control Module B)		V																							
		FCDIM (Front Control/Display Interface Module)	56	V																							
		FCIM (Front Controls Interface Module)	57	V																							
		FCIMB (Front Controls Interface Module B)	58	V																							
		IPMB (Image Processing Module B)	63	V																							
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		BCM (Body Control Module)																									
		ATCM (All Terrain Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		PAM (Parking Assist Control Module)																									
		RDCM (Rear Differential Control Module)																									

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Reggeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
Discovery 4 (LR4)	2014~2015	RLM (Ride Level Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		TCCM (Transfer Case Control Module)																									
		VIM (Vehicle Immobiliser Module)																									
		AHCM (Auxiliary Heater Control Module)																									
		AHU (Audio Head Unit)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		FCDIM (Front Control/Display Interface Module)																									
		FCIM (Front Controls Interface Module)																									
		FCIMB (Front Controls Interface Module B)																									
		HCMB (Headlamp Control Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		PDM (Passenger's Door Module)																									
		KVM (Keyless Vehicle Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
Discovery Sport	2015	PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Regeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
		SUMB (Adaptive Damping Control Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		AHCM (Auxiliary Heater Control Module)																									
		AHU (Incontrol Touch Audio Head Unit)																									
		FCDIM (Front Control/Display Interface Module)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
Freelander 2 (LR2)	2007~2010	PCM (Powertrain Control Module)	SI6 - 3.2 Petrol	V		V		V																			
			DW12 - 2.2 DIESEL (Low Power)	V				V						V				V		V							
			V12 - 2.2 DIESEL with cDPF (Low Pow	V				V						V				V		V							
		TCM (Transmission Control Module)		V		V																					
		ABS (ABS Control Module)		V		V																					
		RCM (Restraints Control Module)		V		V																					
		SASM (Steering Angle Sensor Module)		V		V																					
		ATCM (All Terrain Control Module)		V																							
		BCM (Body Control Module)		V		V																					
		HCM (Headlamp Control Module)		V		V																					
		OCS (Restraints Occupancy System)		V																							
		RDCM (Rear Differential Control Module)		V		V																					
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		ICM (Infotainment Control Module)																									
		IPC (Instrument Cluster Control Module)									V																
		PAM (Parking Assist Control Module)																									
		PDM (Passenger's Door Module)																									
		TRM (Trailer module)																									
			GTDi - 2.0 Petrol (High Power)	V				V																			
			SI6 - 3.2 Petrol	V				V																			

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Reggeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
Freelander 2 (LR2)	2011~2012	PCM (Powertrain Control Module)	DW12 - 2.2 DIESEL (High Power)	V				V						V				V		V							
			/12 - 2.2 DIESEL with cDPF (High Pov	V				V						V				V		V							
			/12 - 2.2 DIESEL with cDPF (Low Pow	V				V						V				V		V							
		TCM (Transmission Control Module)		V																							
		ABS (ABS Control Module)		V																							
		RCM (Restraints Control Module)		V																							
		SASM (Steering Angle Sensor Module)		V																							
		ATCM (All Terrain Control Module)		V																							
		BCM (Body Control Module)		V																							
		HCM (Headlamp Control Module)		V																							
		OCS (Restraints Occupancy System)		V																							
		RDCM (Rear Differential Control Module)		V																							
		DDM (Driver's Door Module)		V																							
		DSM (Driver's Seat Module)		V																							
		HVAC (Heating Ventilation and Air Conditioning Control Module)		V																							
		ICM (Infotainment Control Module)		V																							
		IPC (Instrument Cluster Control Module)		V							V																
		PAM (Parking Assist Control Module)		V																							
		PDM (Passenger's Door Module)		V																							
		TRM (Trailer module)		V																							
Freelander 2 (LR2)	2013~2014	PCM (Powertrain Control Module)		V				V					V														
		TCM (Transmission Control Module)		V																							
		ABS (ABS Control Module)		V																							
		RCM (Restraints Control Module)		V																							
		SASM (Steering Angle Sensor Module)		V																							
		VIM (Vehicle Immobiliser Module)		V																							
		ATCM (All Terrain Control Module)		V																							
		BCM (Body Control Module)		V																							
		HCM (Headlamp Control Module)		V																							
		IPC (Instrument Cluster Control Module)		V																							
		OCS (Restraints Occupancy System)		V																							
		PAM (Parking Assist Control Module)		V																							
		PBM (Parking Brake Control Module)		V																							
		RDCM (Rear Differential Control Module)		V																							

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Regeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
		AHU (Audio Head Unit)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		KVM (Keyless Vehicle Module)																									
		PDM (Passenger's Door Module)																									
		FCDIM (Front Control/Display Interface Module)	56																								
		FCIMB (Front Controls Interface Module B)	58																								
		IPMB (Image Processing Module B)	63																								
Range Rover	2006	PCM (Powertrain Control Module)		V				V																			
		TCM (Transmission Control Module)		V																							
		TCCM (Transfer Case Control Module)		V																							
		VDM (Vehicle dynamics module (ABS))		V																							
		SASM (Steering Angle Sensor Module)		V																							
		FLM (Front Lighting Control Module)		V																							
		IPC (Instrument Cluster Control Module)		V																							
		RLM (Ride Level Control Module)		V																							
		VIM (Vehicle Immobiliser Module)																									
		CDP (CD Player/Changer Module)																									
		RDUM (Remote Driver Utility Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		TEL (Cell Phone Module)	69																								
		TMC (Traffic Message Control Module)	70																								
Range Rover	2007~2009	PCM (Powertrain Control Module)		V				V																			
		TCM (Transmission Control Module)		V																							
		TCCM (Transfer Case Control Module)		V																							
		VDM (Vehicle dynamics module (ABS))		V																							
		RCM (Restraints Control Module)		V																							
		SASM (Steering Angle Sensor Module)		V																							
		ATCM (All Terrain Control Module)		V																							
		FLM (Front Lighting Control Module)		V																							
		IPC (Instrument Cluster Control Module)		V																							
		OCS (Restraints Occupancy System)		V																							
		PBM (Parking Brake Control Module)		V																							
		RDCM (Rear Differential Control Module)		V																							
		RLM (Ride Level Control Module)		V																							

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Regeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
		VIM (Vehicle Immobiliser Module)																									
		CDP (CD Player/Changer Module)																									
		DCSM (Driver's Seat Climate Control Module)																									
		RBM (Running Board Module)																									
		RDUM (Remote Driver Utility Control Module)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		TEL (Cell Phone Module)	69																								
		TMC (Traffic Message Control Module)	70																								
Range Rover	2010~2012	PCM (Powertrain Control Module)	368DT - V8 3.6 Diesel	V				V																			
			368DT - V8 3.6 Diesel with DPF	V				V																			
			448DT - V8 4.4 Diesel	V				V																			
			448DT - V8 4.4 Diesel with DPF	V				V																			
			508PS - AJ V8 5.0 SC Petrol	V				V																			
			508PS - V8 5.0 SC Petrol	V				V																			
			508PN - V8 5.0 NA Petrol	V				V																			
			508PN - AJ V8 5.0 NA Petrol	V				V																			
		TCM (Transmission Control Module)		V																							
		TCCM (Transfer Case Control Module)		V																							
		ABS (ABS Control Module)		V																							
		RCM (Restraints Control Module)		V																							
		SASM (Steering Angle Sensor Module)		V																							
		VIM (Vehicle Immobiliser Module)		V																							
		ADCM (Adaptive Damping Control Module)		V																							
		ATCM (All Terrain Control Module)		V																							
		BCM (Body Control Module)		V																							
		CCM (Adaptive Speed Control Control Module)		V																							
		HCM (Headlamp Control Module)		V																							
		IPC (Instrument Cluster Control Module)		V																							
		OCS (Restraints Occupancy System)		V																							
		PBM (Parking Brake Control Module)		V																							
		RLM (Ride Level Control Module)		V																							
		RDCM (Rear Differential Control Module)																									
		APIM (Accessory Protocol Interface Module)																									
		CDP (CD Player/Changer Module)																									
		DCSM (Driver's Seat Climate Control Module)																									

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Regeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		KVM (Keyless Vehicle Module)																									
		PAM (Parking Assist Control Module)																									
		RDCSM (Rear Seat Climate Control Module)																									
		RDUM (Remote Driver Utility Control Module)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		PDM (Passenger's Door Module)	34																								
		PSM (Passenger's Seat Module)	35																								
		RBM (Running Board Module)	36																								
		IPMB (Image Processing Module B)	63																								
		TEL (Cell Phone Module)	69																								
		PCM (Powertrain Control Module)		V				V																			
		TCM (Transmission Control Module)		V																							
		TCCM (Transfer Case Control Module)		V																							
		GSM (Gear Shift Module)		V																							
		ABS (ABS Control Module)		V																							
		RCM (Restraints Control Module)		V																							
		PSCM (Power Steering Control Module)		V																							
		SASM (Steering Angle Sensor Module)		V																							
		VIM (Vehicle Immobiliser Module)		V																							
		ATCM (All Terrain Control Module)		V																							
		BCM (Body Control Module)		V																							
		CCM (Adaptive Speed Control Control Module)		V																							
		CHCM (Chassis Control Module)		V																							
		CHCMB (Chassis Control Module B)		V																							
		GWM (Gateway Module)		V																							
		HCM (Headlamp Control Module)		V																							
		HVAC (Heating Ventilation and Air Conditioning Control Module)	30	V																							
		IPC (Instrument Cluster Control Module)		V																							
		OCS (Restraints Occupancy System)		V																							
		PAM (Parking Assist Control Module)		V																							

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Regeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
Range Rover	2013	PBM (Parking Brake Control Module)		V																							
		RDCM (Rear Differential Control Module)		V																							
		SPMA (Seatbelt Pretensioner Control Module A)		V																							
		SPMB (Seatbelt Pretensioner Control Module B)		V																							
		DCSM (Driver's Seat Climate Control Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		RBM (Running Board Module)																									
		RDCSM (Rear Seat Climate Control Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		RGTMB (Rear Gate/Trunk Module B)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		RLSM (Rear Left Seat Module)																									
		RRSM (Rear Right Seat Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		FCDIM (Front Control/Display Interface Module)	56																								
		FCIM (Front Controls Interface Module)	57																								
		FCIMB (Front Controls Interface Module B)	58																								
		FCIMC (Front Controls Interface Module C)	59																								
		IPMB (Image Processing Module B)	63																								
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Reggeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
Range Rover	2014-2015	OCS (Restraints Occupancy System)																									
		RDCM (Rear Differential Control Module)																									
		TCCM (Transfer Case Control Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		CHCM (Chassis Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SPMA (Seatbelt Pretensioner Control Module A)																									
		SPMB (Seatbelt Pretensioner Control Module B)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		RBM (Running Board Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		RGTMB (Rear Gate/Trunk Module B)																									
		FCDIM (Front Control/Display Interface Module)																									
		FCIM (Front Controls Interface Module)																									
		FCIMB (Front Controls Interface Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		BCM (Body Control Module)																									

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Reggeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
Range Rover	2016~	CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		OCS (Restraints Occupancy System)																									
		RDCM (Rear Differential Control Module)																									
		TCCM (Transfer Case Control Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		CHCM (Chassis Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SPMA (Seatbelt Pretensioner Control Module A)																									
		SPMB (Seatbelt Pretensioner Control Module B)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		RBM (Running Board Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		RGTMB (Rear Gate/Trunk Module B)																									
		FCDIM (Front Control/Display Interface Module)																									
		FCIM (Front Controls Interface Module)																									
		FCIMB (Front Controls Interface Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		PCM (Powertrain Control Module)	DW12 - 2.2 Diesel (Low power)	V				V																			
			W12 - 2.2 Diesel with cDPF (Low powe	V		V		V					V		V	V	V		V		V						
			DW12 - 2.2 Diesel (High power)	V				V																			
			W12 - 2.2 Diesel with cDPF (High pow	V				V					V		V	V	V		V		V						
			GTDi - 2.0 Petrol (Low power)	V				V																			

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Reggeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
Range Rover Evoque	2012~2013		GTDi - 2.0 Petrol (High power)	V				V																			
		TCM (Transmission Control Module)		V																							
		GSM (Gear Shift Module)		V																							
		GSMB (Gear Shift Module B)		V																							
		ABS (ABS Control Module)		V		V																					
		RCM (Restraints Control Module)		V		V																					
		PSCM (Power Steering Control Module)		V		V																					
		SASM (Steering Angle Sensor Module)		V		V																					
		VIM (Vehicle Immobiliser Module)		V		V																					
			Last DB 2014.07. 30 ->	V																							
		ADCM (Adaptive Damping Control Module)		V		V																					
		ATCM (All Terrain Control Module)		V		V																					
		BCM (Body Control Module)		V		V																					
		HCM (Headlamp Control Module)		V		V																	V				
		IPC (Instrument Cluster Control Module)		V		V																					
		OCS (Restraints Occupancy System)		V		V																					
		PAM (Parking Assist Control Module)		V		V																					
		PBM (Parking Brake Control Module)		V		V																					
		RDCM (Rear Differential Control Module)		V		V																					
		AHCM (Auxiliary Heater Control Module)																									
		AHU (Audio Head Unit)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		KVM (Keyless Vehicle Module)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		FCDIM (Front Control/Display Interface Module)	56																								
		FCIMB (Front Controls Interface Module B)	58																								
		IPMB (Image Processing Module B)	63																								

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Regeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
Range Rover Evoque	2014~2015	PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		TCCM (Transfer Case Control Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SUMB (Adaptive Damping Control Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		AHCM (Auxiliary Heater Control Module)																									
		AHU (Audio Head Unit)																									
		FCDIM (Front Control/Display Interface Module)																									
		FCIMB (Front Controls Interface Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Regeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
Range Rover Evoque	2016	ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SUMB (Adaptive Damping Control Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		AHU (Audio Head Unit)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Reggeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
Range Rover Evoque Convertible	2016~	GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		FTCM (Folding Top Control Module)																									
		FTCMB (Folding Top Control Module B)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SUMB (Adaptive Damping Control Module)																									
		AHU (Incontrol Touch Audio Head Unit)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
Range Rover Sport	2006~2009	PCM (Powertrain Control Module)	276DT - V6 2.7 Diesel	V				V																			
			276DT - V6 2.7 Diesel non cDPF	V				V																			
			406PN - V6 4.0 Petrol	V				V																			
			428PS - AJ V8 4.2 SC Petrol	V				V																			
			448PN - AJ V8 4.4 Petrol	V				V																			
		TCM (Transmission Control Module)		V																							
		TCCM (Transfer Case Control Module)		V																							
		VDM (Vehicle dynamics module (ABS))		V																		V					
		RCM (Restraints Control Module)		V																							
		SASM (Steering Angle Sensor Module)		V																							
		ARCM (Active Roll Control Module)		V																							
		ATCM (All Terrain Control Module)		V																							

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Reggeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
		CCM (Adaptive Speed Control Control Module)		V																							
		FLM (Front Lighting Control Module)		V																							
		PBM (Parking Brake Control Module)		V																					V	V	V
		RDCM (Rear Differential Control Module)		V																							
		RLM (Ride Level Control Module)		V																							
		IPC (Instrument Cluster Control Module)		V					V	V																	
		BCM (Body Control Module)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		PAM (Parking Assist Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		TEL (Cell Phone Module)	69																								
		TMC (Traffic Message Control Module)	70																								
		PCM (Powertrain Control Module)		V																							
		TCM (Transmission Control Module)		V																							
		TCCM (Transfer Case Control Module)		V																							
		ABS (ABS Control Module)		V																							
		RCM (Restraints Control Module)		V																							
		SASM (Steering Angle Sensor Module)		V																							
		VIM (Vehicle Immobiliser Module)		V																							
		ADCM (Adaptive Damping Control Module)		V																							
		ARCM (Active Roll Control Module)		V																							
		ATCM (All Terrain Control Module)		V																							
		BCM (Body Control Module)		V																							
		CCM (Adaptive Speed Control Control Module)		V																							
		HCM (Headlamp Control Module)		V																							
		IPC (Instrument Cluster Control Module)		V								V															
		OCS (Restraints Occupancy System)		V																							
Range Rover Sport	2010~2011	PBM (Parking Brake Control Module)		V																							
		RDCM (Rear Differential Control Module)		V																							
		RLM (Ride Level Control Module)		V																							
		AHCM (Auxiliary Heater Control Module)		V																							
		APIM (Accessory Protocol Interface Module)		V																							
		DDM (Driver's Door Module)		V																							
		DSM (Driver's Seat Module)		V																							

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Regeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
		HCMB (Headlamp Control Module B)		V																							
		HVAC (Heating Ventilation and Air Conditioning Control Module)		V																							
		KVM (Keyless Vehicle Module)		V																							
		PAM (Parking Assist Control Module)		V																							
		PDM (Passenger's Door Module)		V																							
		FCIM (Front Controls Interface Module)	57	V																							
		FCIMB (Front Controls Interface Module B)	58	V																							
		IPMB (Image Processing Module B)	63	V																							
		TEL (Cell Phone Module)	69	V																							
Range Rover Sport	2012~2013	PCM (Powertrain Control Module)	508PN - V8 5.0 NA Petrol	V				V																			
			508PS - V8 5.0 SC Petrol	V				V																			
			306DT - V6 3.0 Diesel	V				V																			
			306DT - V6 3.0 Diesel with cDPF	V				V																			
			368DT - V8 3.6 Diesel	V				V																			
		TCCM (Transfer Case Control Module)		V																							
		TCM (Transmission Control Module)		V																							
		GSM (Gear Shift Module)		V																							
		ABS (ABS Control Module)		V																							
		RCM (Restraints Control Module)		V																							
		SASM (Steering Angle Sensor Module)		V																							
		VIM (Vehicle Immobiliser Module)		V																							
		ADCM (Adaptive Damping Control Module)		V																							
		ARCM (Active Roll Control Module)		V																							
		ATCM (All Terrain Control Module)		V																							
		BCM (Body Control Module)		V																							
		CCM (Adaptive Speed Control Control Module)		V																							
		HCM (Headlamp Control Module)		V																							
		IPC (Instrument Cluster Control Module)		V																							
		OCS (Restraints Occupancy System)		V																							
		PBM (Parking Brake Control Module)		V																							
		RDCM (Rear Differential Control Module)		V																							
		RLM (Ride Level Control Module)		V																							
		AHCM (Auxiliary Heater Control Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Reggeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		KVM (Keyless Vehicle Module)																									
		PAM (Parking Assist Control Module)																									
		PDM (Passenger's Door Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		FCDIM (Front Control/Display Interface Module)	56																								
		FCIM (Front Controls Interface Module)	57																								
		FCIMB (Front Controls Interface Module B)	58																								
		IPMB (Image Processing Module B)	63																								
New Range Rover Sport	2014~2015	PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		RDCM (Rear Differential Control Module)																									
		TCCM (Transfer Case Control Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		CHCM (Chassis Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SPMA (Seatbelt Pretensioner Control Module A)																									
		SPMB (Seatbelt Pretensioner Control Module B)																									
		DDM (Driver's Door Module)																									

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Reggeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		RBM (Running Board Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		FCDIM (Front Control/Display Interface Module)																									
		FCIM (Front Controls Interface Module)																									
		FCIMB (Front Controls Interface Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		OCS (Restraints Occupancy System)																									
		RDCM (Rear Differential Control Module)																									
		TCCM (Transfer Case Control Module)																									
		VIM (Vehicle Immobiliser Module)																									

Vehicle	Year	System 1	System 2	DTC Analysis	Freeze frame	Data Analysis	Actuator	ECU Information Display	Service Interval Reset(Petrol)	Service Interval Reset(Diesel)	Service Interval Reset	Service Interval Reset	Service Interval Reset	Oil Service Counter Reset	Oil Service Counter Reset	Diesel Particulate Filter Dynamic Regeneration	Reset Water in Fuel Detection	Diesel Particle Filter Differential Pressure	Diesel Particle Filter Differential Pressure	Diesel Particulate Filter Replacement	Diesel Particulate Filter Replacement	Brake Bleed (Diesel Only)	Headlamp Control Module System Calibration	Longitudinal Accelerometer Calibration	Drive The Parking Brake To The Mounting	Drive The Parking Brake To The Latching	Parking Brake Unjam Procedure
New Range Rover Sport	2016~	ATCM (All Terrain Control Module)																									
		CHCM (Chassis Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SPMA (Seatbelt Pretensioner Control Module A)																									
		SPMB (Seatbelt Pretensioner Control Module B)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		RBM (Running Board Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		FCDIM (Front Control/Display Interface Module)																									
		FCIM (Front Controls Interface Module)																									
		FCIMB (Front Controls Interface Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
Defender	2011	PCM (Powertrain Control Module)														V	V										
		ABS (ABS Control Module)																									
		IPC (Instrument Cluster Control Module)																									
	2012~2015	PCM (Powertrain Control Module)																									
		ABS (ABS Control Module)																									
		IPC (Instrument Cluster Control Module)																									
Discovery 3 (LR3)	2005~2009	PCM (Powertrain Control Module)	406PN - V6 4.0 Petrol																								
			276DT - V6 2.7 DIESEL non cDPF																								
			276DT - V6 2.7 DIESEL with cDPF																								
			448PN - AJ V8 4.4 Petrol																								
		TCM (Transmission Control Module)																									
		TCCM (Transfer Case Control Module)																									
		VDM (Vehicle dynamics module (ABS))																									
		RCM (Restraints Control Module)																									
		SASM (Steering Angle Sensor Module)										0															
		ATCM (All Terrain Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		FLM (Front Lighting Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		RDCM (Rear Differential Control Module)																									
		RLM (Ride Level Control Module)																									
		ACM (Audio Front Control Module)																									
		BCM (Body Control Module)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		PAM (Parking Assist Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		TEL (Cell Phone Module)	69																								
		TMC (Traffic Message Control Module)	70																								
		PCM (Powertrain Control Module)																V	V	V	V	V	V				
		TCM (Transmission Control Module)																									
		TCCM (Transfer Case Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		VIM (Vehicle Immobiliser Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
Discovery 4 (LR4)	2010~2011	ATCM (All Terrain Control Module)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		HCM (Headlamp Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		OCS (Restraints Occupancy System)																									
		PBM (Parking Brake Control Module)																									
		RDCM (Rear Differential Control Module)																									
		RLM (Ride Level Control Module)																							V	V	V
		AHCM (Auxiliary Heater Control Module)																									
		APIM (Accessory Protocol Interface Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		KVM (Keyless Vehicle Module)																									
		PAM (Parking Assist Control Module)																									
		PDM (Passenger's Door Module)																									
		FCDIM (Front Control/Display Interface Module)	56																								
		FCIM (Front Controls Interface Module)	57																								
		FCIMB (Front Controls Interface Module B)	58																								
		IPMB (Image Processing Module B)	63																								
		TEL (Cell Phone Module)	69																								
		PCM (Powertrain Control Module)	508PN - V8 5.0 Petrol																								
			508PN - V8 5.0 NA Petrol																								
			276DT - V6 2.7 Diesel non cDPF																								
			306DT - V6 3.0 Hi Pwr Diesel non cDP																								
			306DT - V6 3.0 Hi Pwr Diesel with cDP																								
			306DT - V6 3.0 Lo Pwr Diesel with cDP																								
		TCM (Transmission Control Module)																									
		TCCM (Transfer Case Control Module)																									
		GSM (Gear Shift Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		VIM (Vehicle Immobiliser Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
Discovery 4 (LR4)	2012~2013	ATCM (All Terrain Control Module)																									
		BCM (Body Control Module)																									
		HCM (Headlamp Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		OCS (Restraints Occupancy System)																									
		PBM (Parking Brake Control Module)																									
		RLM (Ride Level Control Module)																									
		RDCM (Rear Differential Control Module)																									
		AHCM (Auxiliary Heater Control Module)																									
		AHU (Audio Head Unit)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		KVM (Keyless Vehicle Module)																									
		PAM (Parking Assist Control Module)																									
		PDM (Passenger's Door Module)																									
		HCMB (Headlamp Control Module B)																									
		FCDIM (Front Control/Display Interface Module)	56																								
		FCIM (Front Controls Interface Module)	57																								
		FCIMB (Front Controls Interface Module B)	58																								
		IPMB (Image Processing Module B)	63																								
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		BCM (Body Control Module)																									
		ATCM (All Terrain Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		PAM (Parking Assist Control Module)																									
		RDCM (Rear Differential Control Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
Discovery 4 (LR4)	2014~2015	RLM (Ride Level Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		TCCM (Transfer Case Control Module)																									
		VIM (Vehicle Immobiliser Module)																									
		AHCM (Auxiliary Heater Control Module)																									
		AHU (Audio Head Unit)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		FCDIM (Front Control/Display Interface Module)																									
		FCIM (Front Controls Interface Module)																									
		FCIMB (Front Controls Interface Module B)																									
		HCMB (Headlamp Control Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		PDM (Passenger's Door Module)																									
		KVM (Keyless Vehicle Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
Discovery Sport	2015	PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
		SUMB (Adaptive Damping Control Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		AHCM (Auxiliary Heater Control Module)																									
		AHU (Incontrol Touch Audio Head Unit)																									
		FCDIM (Front Control/Display Interface Module)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
Freelander 2 (LR2)	2007~2010	PCM (Powertrain Control Module)	SI6 - 3.2 Petrol																								
			DW12 - 2.2 DIESEL (Low Power)																								
			/12 - 2.2 DIESEL with cDPF (Low Pow																								
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)						V	V	V	V																
		RCM (Restraints Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		ATCM (All Terrain Control Module)																									
		BCM (Body Control Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		RDCM (Rear Differential Control Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		ICM (Infotainment Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PAM (Parking Assist Control Module)																									
		PDM (Passenger's Door Module)																									
		TRM (Trailer module)																									
			GTDi - 2.0 Petrol (High Power)																								
			SI6 - 3.2 Petrol																								

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
Freelander 2 (LR2)	2011~2012	PCM (Powertrain Control Module)	DW12 - 2.2 DIESEL (High Power)																								
			/12 - 2.2 DIESEL with cDPF (High Pov																								
			/12 - 2.2 DIESEL with cDPF (Low Pow																								
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		ATCM (All Terrain Control Module)																									
		BCM (Body Control Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		RDCM (Rear Differential Control Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		ICM (Infotainment Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PAM (Parking Assist Control Module)																									
		PDM (Passenger's Door Module)																									
		TRM (Trailer module)																									
Freelander 2 (LR2)	2013~2014	PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		BCM (Body Control Module)																									
		HCM (Headlamp Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		OCS (Restraints Occupancy System)																									
		PAM (Parking Assist Control Module)																									
		PBM (Parking Brake Control Module)																									
		RDCM (Rear Differential Control Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
		AHU (Audio Head Unit)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		KVM (Keyless Vehicle Module)																									
		PDM (Passenger's Door Module)																									
		FCDIM (Front Control/Display Interface Module)	56																								
		FCIMB (Front Controls Interface Module B)	58																								
		IPMB (Image Processing Module B)	63																								
Range Rover	2006	PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		TCCM (Transfer Case Control Module)																									
		VDM (Vehicle dynamics module (ABS))																									
		SASM (Steering Angle Sensor Module)																									
		FLM (Front Lighting Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		RLM (Ride Level Control Module)																									
		VIM (Vehicle Immobiliser Module)																									
		CDP (CD Player/Changer Module)																									
		RDUM (Remote Driver Utility Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		TEL (Cell Phone Module)	69																								
		TMC (Traffic Message Control Module)	70																								
Range Rover	2007~2009	PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		TCCM (Transfer Case Control Module)																									
		VDM (Vehicle dynamics module (ABS))																									
		RCM (Restraints Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		ATCM (All Terrain Control Module)																									
		FLM (Front Lighting Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		OCS (Restraints Occupancy System)																									
		PBM (Parking Brake Control Module)																									
		RDCM (Rear Differential Control Module)																									
		RLM (Ride Level Control Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
		VIM (Vehicle Immobiliser Module)																									
		CDP (CD Player/Changer Module)																									
		DCSM (Driver's Seat Climate Control Module)																									
		RBM (Running Board Module)																									
		RDUM (Remote Driver Utility Control Module)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		TEL (Cell Phone Module)	69																								
		TMC (Traffic Message Control Module)	70																								
Range Rover	2010~2012	PCM (Powertrain Control Module)	368DT - V8 3.6 Diesel																								
			368DT - V8 3.6 Diesel with DPF																								
			448DT - V8 4.4 Diesel																								
			448DT - V8 4.4 Diesel with DPF																								
			508PS - AJ V8 5.0 SC Petrol																								
			508PS - V8 5.0 SC Petrol																								
			508PN - V8 5.0 NA Petrol																								
			508PN - AJ V8 5.0 NA Petrol																								
		TCM (Transmission Control Module)																									
		TCCM (Transfer Case Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ADCM (Adaptive Damping Control Module)																									
		ATCM (All Terrain Control Module)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		HCM (Headlamp Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		OCS (Restraints Occupancy System)																									
		PBM (Parking Brake Control Module)																									
		RLM (Ride Level Control Module)																									
		RDCM (Rear Differential Control Module)																									
		APIM (Accessory Protocol Interface Module)																									
		CDP (CD Player/Changer Module)																									
		DCSM (Driver's Seat Climate Control Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		KVM (Keyless Vehicle Module)																									
		PAM (Parking Assist Control Module)																									
		RDCSM (Rear Seat Climate Control Module)																									
		RDUM (Remote Driver Utility Control Module)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		PDM (Passenger's Door Module)	34																								
		PSM (Passenger's Seat Module)	35																								
		RBM (Running Board Module)	36																								
		IPMB (Image Processing Module B)	63																								
		TEL (Cell Phone Module)	69																								
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		TCCM (Transfer Case Control Module)																									
		GSM (Gear Shift Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		CHCM (Chassis Control Module)																									
		CHCMB (Chassis Control Module B)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)	30																								
		IPC (Instrument Cluster Control Module)																									
		OCS (Restraints Occupancy System)																									
		PAM (Parking Assist Control Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
Range Rover	2013	PBM (Parking Brake Control Module)																									
		RDCM (Rear Differential Control Module)																									
		SPMA (Seatbelt Pretensioner Control Module A)																									
		SPMB (Seatbelt Pretensioner Control Module B)																									
		DCSM (Driver's Seat Climate Control Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		RBM (Running Board Module)																									
		RDCSM (Rear Seat Climate Control Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		RGTMB (Rear Gate/Trunk Module B)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		RLSM (Rear Left Seat Module)																									
		RRSM (Rear Right Seat Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		FCDIM (Front Control/Display Interface Module)	56																								
		FCIM (Front Controls Interface Module)	57																								
		FCIMB (Front Controls Interface Module B)	58																								
		FCIMC (Front Controls Interface Module C)	59																								
		IPMB (Image Processing Module B)	63																								
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
Range Rover	2014-2015	OCS (Restraints Occupancy System)																									
		RDCM (Rear Differential Control Module)																									
		TCCM (Transfer Case Control Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		CHCM (Chassis Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SPMA (Seatbelt Pretensioner Control Module A)																									
		SPMB (Seatbelt Pretensioner Control Module B)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		RBM (Running Board Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		RGTMB (Rear Gate/Trunk Module B)																									
		FCDIM (Front Control/Display Interface Module)																									
		FCIM (Front Controls Interface Module)																									
		FCIMB (Front Controls Interface Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		BCM (Body Control Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
Range Rover	2016~	CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		OCS (Restraints Occupancy System)																									
		RDCM (Rear Differential Control Module)																									
		TCCM (Transfer Case Control Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		CHCM (Chassis Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SPMA (Seatbelt Pretensioner Control Module A)																									
		SPMB (Seatbelt Pretensioner Control Module B)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		RBM (Running Board Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		RGTMB (Rear Gate/Trunk Module B)																									
		FCDIM (Front Control/Display Interface Module)																									
		FCIM (Front Controls Interface Module)																									
		FCIMB (Front Controls Interface Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		PCM (Powertrain Control Module)	DW12 - 2.2 Diesel (Low power)																								
			W12 - 2.2 Diesel with cDPF (Low powe																								
			DW12 - 2.2 Diesel (High power)																								
			W12 - 2.2 Diesel with cDPF (High pow																								
			GTDi - 2.0 Petrol (Low power)																								

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
Range Rover Evoque	2012~2013		GTDi - 2.0 Petrol (High power)																								
		TCM (Transmission Control Module)											V	V													
		GSM (Gear Shift Module)																									
		GSMB (Gear Shift Module B)																									
		ABS (ABS Control Module)						V	V	V	V	V															
		RCM (Restraints Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		VIM (Vehicle Immobiliser Module)																									
			Last DB 2014.07. 30 ->																								
		ADCM (Adaptive Damping Control Module)																									
		ATCM (All Terrain Control Module)																									
		BCM (Body Control Module)																									
		HCM (Headlamp Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		OCS (Restraints Occupancy System)																									
		PAM (Parking Assist Control Module)																									
		PBM (Parking Brake Control Module)		V	V	V	V																				
		RDCM (Rear Differential Control Module)																									
		AHCM (Auxiliary Heater Control Module)																									
		AHU (Audio Head Unit)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		KVM (Keyless Vehicle Module)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		FCDIM (Front Control/Display Interface Module)	56																								
		FCIMB (Front Controls Interface Module B)	58																								
		IPMB (Image Processing Module B)	63																								

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
Range Rover Evoque	2014~2015	PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		TCCM (Transfer Case Control Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SUMB (Adaptive Damping Control Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		AHCM (Auxiliary Heater Control Module)																									
		AHU (Audio Head Unit)																									
		FCDIM (Front Control/Display Interface Module)																									
		FCIMB (Front Controls Interface Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
Range Rover Evoque	2016	ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SUMB (Adaptive Damping Control Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		AHU (Audio Head Unit)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
Range Rover Evoque Convertible	2016~	GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		FTCM (Folding Top Control Module)																									
		FTCMB (Folding Top Control Module B)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SUMB (Adaptive Damping Control Module)																									
		AHU (Incontrol Touch Audio Head Unit)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
Range Rover Sport	2006~2009	PCM (Powertrain Control Module)	276DT - V6 2.7 Diesel																								
			276DT - V6 2.7 Diesel non cDPF																								
			406PN - V6 4.0 Petrol																								
			428PS - AJ V8 4.2 SC Petrol																								
			448PN - AJ V8 4.4 Petrol																								
		TCM (Transmission Control Module)																									
		TCCM (Transfer Case Control Module)																									
		VDM (Vehicle dynamics module (ABS))																									
		RCM (Restraints Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		ARCM (Active Roll Control Module)																									
		ATCM (All Terrain Control Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
		CCM (Adaptive Speed Control Control Module)																									
		FLM (Front Lighting Control Module)																									
		PBM (Parking Brake Control Module)													V												
		RDCM (Rear Differential Control Module)																									
		RLM (Ride Level Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		BCM (Body Control Module)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		PAM (Parking Assist Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		TEL (Cell Phone Module)	69																								
		TMC (Traffic Message Control Module)	70																								
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		TCCM (Transfer Case Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ADCM (Adaptive Damping Control Module)																									
		ARCM (Active Roll Control Module)																									
		ATCM (All Terrain Control Module)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		HCM (Headlamp Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		OCS (Restraints Occupancy System)																									
Range Rover Sport	2010~2011	PBM (Parking Brake Control Module)																									
		RDCM (Rear Differential Control Module)																									
		RLM (Ride Level Control Module)																									
		AHCM (Auxiliary Heater Control Module)																									
		APIM (Accessory Protocol Interface Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
		HCMB (Headlamp Control Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		KVM (Keyless Vehicle Module)																									
		PAM (Parking Assist Control Module)																									
		PDM (Passenger's Door Module)																									
		FCIM (Front Controls Interface Module)	57																								
		FCIMB (Front Controls Interface Module B)	58																								
		IPMB (Image Processing Module B)	63																								
		TEL (Cell Phone Module)	69																								
Range Rover Sport	2012~2013	PCM (Powertrain Control Module)	508PN - V8 5.0 NA Petrol																								
			508PS - V8 5.0 SC Petrol																								
			306DT - V6 3.0 Diesel																								
			306DT - V6 3.0 Diesel with cDPF																								
			368DT - V8 3.6 Diesel																								
		TCCM (Transfer Case Control Module)																									
		TCM (Transmission Control Module)																									
		GSM (Gear Shift Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ADCM (Adaptive Damping Control Module)																									
		ARCM (Active Roll Control Module)																									
		ATCM (All Terrain Control Module)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		HCM (Headlamp Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		OCS (Restraints Occupancy System)																									
		PBM (Parking Brake Control Module)																									
		RDCM (Rear Differential Control Module)																									
		RLM (Ride Level Control Module)																									
		AHCM (Auxiliary Heater Control Module)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		KVM (Keyless Vehicle Module)																									
		PAM (Parking Assist Control Module)																									
		PDM (Passenger's Door Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		FCDIM (Front Control/Display Interface Module)	56																								
		FCIM (Front Controls Interface Module)	57																								
		FCIMB (Front Controls Interface Module B)	58																								
		IPMB (Image Processing Module B)	63																								
New Range Rover Sport	2014~2015	PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		HCM (Headlamp Control Module)																									
		OCS (Restraints Occupancy System)																									
		RDCM (Rear Differential Control Module)																									
		TCCM (Transfer Case Control Module)																									
		VIM (Vehicle Immobiliser Module)																									
		ATCM (All Terrain Control Module)																									
		CHCM (Chassis Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SPMA (Seatbelt Pretensioner Control Module A)																									
		SPMB (Seatbelt Pretensioner Control Module B)																									
		DDM (Driver's Door Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
		DSM (Driver's Seat Module)																									
		HCMB (Headlamp Control Module B)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		RBM (Running Board Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		FCDIM (Front Control/Display Interface Module)																									
		FCIM (Front Controls Interface Module)																									
		FCIMB (Front Controls Interface Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									
		PCM (Powertrain Control Module)																									
		TCM (Transmission Control Module)																									
		ABS (ABS Control Module)																									
		RCM (Restraints Control Module)																									
		IPC (Instrument Cluster Control Module)																									
		PBM (Parking Brake Control Module)																									
		TPM (Tyre Pressure Monitoring System)																									
		BCM (Body Control Module)																									
		CCM (Adaptive Speed Control Control Module)																									
		GSM (Gear Shift Module)																									
		GWM (Gateway Module)																									
		OCS (Restraints Occupancy System)																									
		RDCM (Rear Differential Control Module)																									
		TCCM (Transfer Case Control Module)																									
		VIM (Vehicle Immobiliser Module)																									

Vehicle	Year	System 1	System 2	Longitudinal Accelerometer Calibration	Parking Brake Pad Replacement - Release to	Parking Brake Pad Replacement - Exit	Parking Brake Activation	Lateral Accelerometer Calibration	Pressure Sensor Calibration	Roll Rate Sensor Calibration	Longitudinal Accelerometer Calibration	Steering Angle Sensor Calibration	Transmission control module oil counter reset	Gear selector sensor calibration	Longitudinal Accelerometer Calibration	High Pressure Fuel Pump Replacement Reset	Injector Replacement	Oxygen Sensor	Fuel Lift Pump	Turbine Shut-off Valve	Oil Service Counter Reset	Trottle Valve Actuator	Oxidane Catalyst	Injector Replacement	Air-suspension deflation	Air-suspension inflation	Set/un-set air suspension geometry set-up
New Range Rover Sport	2016~	ATCM (All Terrain Control Module)																									
		CHCM (Chassis Control Module)																									
		PAM (Parking Assist Control Module)																									
		PSCM (Power Steering Control Module)																									
		SASM (Steering Angle Sensor Module)																									
		SPMA (Seatbelt Pretensioner Control Module A)																									
		SPMB (Seatbelt Pretensioner Control Module B)																									
		DDM (Driver's Door Module)																									
		DSM (Driver's Seat Module)																									
		PDM (Passenger's Door Module)																									
		PSM (Passenger's Seat Module)																									
		RBM (Running Board Module)																									
		KVM (Keyless Vehicle Module)																									
		RGTM (Rear Gate/Trunk Module)																									
		FCDIM (Front Control/Display Interface Module)																									
		FCIM (Front Controls Interface Module)																									
		FCIMB (Front Controls Interface Module B)																									
		HVAC (Heating Ventilation and Air Conditioning Control Module)																									
		IPMB (Image Processing Module B)																									
		RHVAC (Rear Heating Ventilation and Air Conditioning Control Module)																									
		SODL (Side Object Detection - Left)																									
		SODR (Side Object Detection - Right)																									

Year	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	AT/CVT Learning Value Initialization	G Sensor 0 Point Learning Start	CVT Hydraulic Pressure Learning Start	Injector ID Check	Injector Compensation	Injector Class Verification	Injector Class Set	Supply Pump Initializtion	AT Learning Value Initialization	DPF deterioration record clear	A/F sensor compensation Reset	Crank time compensation reset	Catalyst record clear	Parts exchange	Air Bleeder	[VSC Actuator]Intake System Air Bleeder	[VSC Actuator]Decompression System Air Bleeder	[ECB]Brake Control Prohibition	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialize	Back Up Memory Clear	VSC System 0 Point Clear	Torque sensor adjustment	Rotational Angle Sensor Calibration	Steering angle adjust	Key code erasure	Key code registration	Servo motor initialization	Wireless code erasure	Wireless code registration	Reset Memory	Body control module Initialization	Communication check	System Identification	Initializtion of immobilizer	Auto Registration Closure	Test Mode	Check Mode	Maintenance Mode 2WD (Exhaust Measurement)	Maintenance Mode 2WD (TRC Forbidden)	Maintenance Mode 4WD (Exhaust Measurement)	Maintenance Mode 4WD (TRC Forbidden)	Maintenance Mode 2WD	Maintenance Mode 4WD	Battery Control Data Initialization	Vehicle Mileage Write	Clutch Adjust Count	Pilot Quantity Learning(Detail)	Pilot Quantity Learning	Pilot Quantity Learning Values Reset	Pilot Quantity Learning Values Clear	Catalyst Record Read/Write	Catalyst Record Transferring
16PIN CONNECTOR	TCCS(Engine/AT)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										V								V			V				V								V		V	V	V	V	V	V
16PIN CONNECTOR	TCCS2(Engine/AT)	V	V																																																								
16PIN CONNECTOR	Transmission(ECT/SMT/MMT)	V	V	V	V	V	V													V	V								V								V							V									V							
16PIN CONNECTOR	Hybrid Vehicle	V	V	V	V																								V								V							V	V	V	V	V	V	V	V								
16PIN CONNECTOR	Mild Hybrid Vehicle	V	V																																																								
16PIN CONNECTOR	Hybrid Vehicle Battery	V	V	V	V																																																							
16PIN CONNECTOR	ABS/VSC	V	V	V	V																V	V	V	V	V	V	V	V	V														V																
16PIN CONNECTOR	ABS/VSC/ARS	V	V	V	V																V							V															V																
16PIN CONNECTOR	Air Suspension/TEMS/AHC	V	V	V	V																																																						
16PIN CONNECTOR	Stabilizer	V	V																																																								
16PIN CONNECTOR	Electric Parking Brake	V	V	V	V																								V																															
16PIN CONNECTOR	ARS(Active Rear Steer)	V	V	V	V																																																						
16PIN CONNECTOR	SRS Airbag	V	V	V																																																							
16PIN CONNECTOR	4WD(4 Wheel Drive)	V	V	V	V																								V																															
16PIN CONNECTOR	EPS(Electric Power Steering)	V	V	V																											V	V																												
16PIN CONNECTOR	Radar Cruise Control	V	V	V																																																							
16PIN CONNECTOR	Radar Cruise Control(HV)	V	V	V																																																							
16PIN CONNECTOR	Stop And Go	V	V	V	V																																																						
16PIN CONNECTOR	VGRS(Variable Gear Ratio Steering)	V	V	V																													V																											
16PIN CONNECTOR	Immobiliser	V	V	V	V	V																												V	V								V	V															
16PIN CONNECTOR	Precrash Safety System	V	V	V	V																																																						
16PIN CONNECTOR	IPA(Intelligent Parking Assist)	V	V	V																																																							
16PIN CONNECTOR	Combination meter	V	V	V	V																																																						
16PIN CONNECTOR	EMS(Energy Management System)	V	V																																																								
16PIN CONNECTOR	Motor Generator	V	V	V																																																							
16PIN CONNECTOR	LKA(Lane Keeping Assist)	V	V																																																								
16PIN CONNECTOR	Active Stabilizer(Front)	V	V																																																								
16PIN CONNECTOR	Active Stabilizer(Rear)	V	V																																																								
16PIN CONNECTOR	Lane Departure Alert	V	V	V	V																																																						
16PIN CONNECTOR	Front Recognition Camera	V	V	V	V																																																						
16PIN CONNECTOR	Transmission Control	V	V	V																																																							
16PIN CONNECTOR	E-ACM(Electric Active Mount)	V	V	V	V																																																						
16PIN CONNECTOR	FCHV(Fuel Cell Hybrid Vehicle)		V		V																																																							
16PIN CONNECTOR	Vehicle Control	V	V	V	V																																																						
16PIN CONNECTOR	Grill Shutter	V	V	V	V																																																						
16PIN CONNECTOR	Plug-in Control(HV)	V	V	V																																									V														
16PIN CONNECTOR	KDSS(Kinetic Dynamic Suspension)	V	V	V	V																																																						
16PIN CONNECTOR	Tire Pressure Warning System	V	V	V																																																							
16PIN CONNECTOR	Charging Control	V	V	V	V																																																						
16PIN CONNECTOR	Starting Control	V	V	V	V																																																						
16PIN CONNECTOR	Gateway	V	V																																																								
16PIN CONNECTOR	Body	V	V	V	V																															V		V																					

Year	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	AT/CVT Learning Value Initialization	G Sensor 0 Point Learning Start	CVT Hydraulic Pressure Learning Start	Injector ID Check	Injector Compensation	Injector Class Verification	Injector Class Set	Supply Pump Initializtion	AT Learning Value Initialization	DPF deterioration record clear	A/F sensor compensation Reset	Crank time compensation reset	Catalyst record clear	Parts exchange	Air Bleeder	[VSC Actuator]Intake System Air Bleeder	[VSC Actuator]Decompression System Air Bleeder	[ECB]Brake Control Prohibition	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialize	Back Up Memory Clear	VSC System 0 Point Clear	Torque sensor adjustment	Rotational Angle Sensor Calibration	Steering angle adjust	Key code erasure	Key code registration	Servo motor initialization	Wireless code erasure	Wireless code registration	Reset Memory	Body control module Initialization	Communication check	System Identification	Initializtion of immobilizer	Auto Registration Closure	Test Mode	Check Mode	Maintenance Mode 2WD (Exhaust Measurement)	Maintenance Mode 2WD (TRC Forbidden)	Maintenance Mode 4WD (Exhaust Measurement)	Maintenance Mode 4WD (TRC Forbidden)	Maintenance Mode 2WD	Maintenance Mode 4WD	Battery Control Data Initialization	Vehicle Mileage Write	Clutch Adjust Count	Pilot Quantity Learning(Detail)	Pilot Quantity Learning	Pilot Quantity Learning Values Reset	Pilot Quantity Learning Values Clear	Catalyst Record Read/Write	Catalyst Record Transferring
16PIN CONNECTOR	Body No.2	V	V																																																															
16PIN CONNECTOR	Body No.3	V	V	V	V																																																													
16PIN CONNECTOR	Body No.4	V	V	V	V																																																													
16PIN CONNECTOR	Body No.5	V	V	V	V																																																													
16PIN CONNECTOR	Hybrid Gateway	V	V																																																															
16PIN CONNECTOR	ECB Gateway	V	V	V																																																														
16PIN CONNECTOR	ECM Gateway	V	V	V																																																														
16PIN CONNECTOR	PM1 gateway	V	V	V																																																														
16PIN CONNECTOR	PM2 gateway	V	V	V																																																														
16PIN CONNECTOR	Accessory Gateway	V	V																																																															
16PIN CONNECTOR	Master Switch	V	V	V	V																																																													
16PIN CONNECTOR	Combination Switch	V	V	V																																																														
16PIN CONNECTOR	Rear Console Switch	V	V																																																															
16PIN CONNECTOR	Air Conditioner	V	V	V	V																														V																																
16PIN CONNECTOR	Tilt And Telescopic	V	V	V	V																																																													
16PIN CONNECTOR	Driver Door(Mirror)	V	V	V	V																																																													
16PIN CONNECTOR	Passenger Door	V	V	V	V																																																													
16PIN CONNECTOR	Rear Right Door	V	V	V	V																																																													
16PIN CONNECTOR	Rear Left Door	V	V	V	V																																																													
16PIN CONNECTOR	Back Door	V	V	V	V																																																													
16PIN CONNECTOR	Driver Door Motor	V	V	V	V																																	V																											
16PIN CONNECTOR	Passenger Door Motor	V	V	V	V																																	V																											
16PIN CONNECTOR	Rear Right Door Motor	V	V	V	V																																	V																											
16PIN CONNECTOR	Rear Left Door Motor	V	V	V	V																																	V																											
16PIN CONNECTOR	Driver Seat	V	V	V	V																																																													
16PIN CONNECTOR	Passenger Seat	V	V	V	V																																																													
16PIN CONNECTOR	Rear Right Seat	V	V	V	V																																																													
16PIN CONNECTOR	Rear Left Seat	V	V	V	V																																																													
16PIN CONNECTOR	Driver Seat Switch	V	V	V	V																																																													
16PIN CONNECTOR	Rear Right Seat Switch	V	V																																																															
16PIN CONNECTOR	Front Right Seat A/C	V	V	V	V																																																													
16PIN CONNECTOR	Front Left Seat A/C	V	V	V	V																																																													
16PIN CONNECTOR	Rear Right Seat A/C	V	V	V	V																																																													
16PIN CONNECTOR	Rear Left Seat A/C	V	V	V	V																																																													
16PIN CONNECTOR	Slide Roof	V	V	V	V																																																													
16PIN CONNECTOR	Rain Sensor	V	V	V																																																														
16PIN CONNECTOR	Wiper			V	V																																																													
16PIN CONNECTOR	Occupant Detection	V	V	V																																																														
16PIN CONNECTOR	Night View	V	V																																																															
16PIN CONNECTOR	Steering Pad(Pad Switch)	V	V	V																																																														
16PIN CONNECTOR	Power Source Control	V	V	V	V																																																													
16PIN CONNECTOR	Electric Power Control	V	V																																																															

Year	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	AT/CVT Learning Value Initialization	G Sensor 0 Point Learning Start	CVT Hydraulic Pressure Learning Start	Injector ID Check	Injector Compensation	Injector Class Verification	Injector Class Set	Supply Pump Initializtion	AT Learning Value Initialization	DPF deterioration record clear	A/F sensor compensation Reset	Crank time compensation reset	Catalyst record clear	Parts exchange	Air Bleeder	[VSC Actuator]Intake System Air Bleeder	[VSC Actuator]Decompression System Air Bleeder	[ECB]Brake Control Prohibition	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialize	Back Up Memory Clear	VSC System 0 Point Clear	Torque sensor adjustment	Rotational Angle Sensor Calibration	Steering angle adjust	Key code erasure	Key code registration	Servo motor initialization	Wireless code erasure	Wireless code registration	Reset Memory	Body control module Initialization	Communication check	System Identification	Initializtion of immobilizer	Auto Registration Closure	Test Mode	Check Mode	Maintenance Mode 2WD (Exhaust Measurement)	Maintenance Mode 2WD (TRC Forbidden)	Maintenance Mode 4WD (Exhaust Measurement)	Maintenance Mode 4WD (TRC Forbidden)	Maintenance Mode 2WD	Maintenance Mode 4WD	Battery Control Data Initialization	Vehicle Mileage Write	Clutch Adjust Count	Pilot Quantity Learning(Detail)	Pilot Quantity Learning	Pilot Quantity Learning Values Reset	Pilot Quantity Learning Values Clear	Catalyst Record Read/Write	Catalyst Record Transferring
16PIN CONNECTOR	Entry And Start	V	V	V	V																												V	V						V																								
16PIN CONNECTOR	Theft Deterrent System	V	V	V	V																																																										
16PIN CONNECTOR	Clearance Sonar	V	V	V	V																																																										
16PIN CONNECTOR	Retractable Hard Top	V	V																																																												
16PIN CONNECTOR	Left Seat Mirror	V	V	V	V																																																										
16PIN CONNECTOR	Right Seat Mirror	V	V	V	V																																																										
16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)	V	V	V	V																																																										
16PIN CONNECTOR	WIL Gateway	V	V																																																												
16PIN CONNECTOR	Remote Security	V	V																																																												
16PIN CONNECTOR	Driver Seat Act Headrest	V	V																																																												
16PIN CONNECTOR	Help Net Gateway	V	V																																																												
16PIN CONNECTOR	Central Gateway	V	V	V																																																											
16PIN CONNECTOR	Precrash 2	V	V	V	V																																																										
16PIN CONNECTOR	Passenger Seat Act Headrest	V	V																																																												
16PIN CONNECTOR	Navigation System	V	V																																																												
16PIN CONNECTOR	Remote Engine Starter	V	V	V																																																											
16PIN CONNECTOR	Panoramic View Monitor	V	V	V																																																											
16PIN CONNECTOR	Blind Spot Monitor Master	V	V	V																																																											
16PIN CONNECTOR	Blind Spot Monitor Slave	V	V	V																																																											
16PIN CONNECTOR	Active Sound Control	V	V	V	V																																																										
16PIN CONNECTOR	Multi Bus Gateway	V	V																																																												
16PIN CONNECTOR	Multi Bus Monitor1	V	V																																																												
16PIN CONNECTOR	Multi Bus Monitor2	V	V																																																												
16PIN CONNECTOR	Vehicle Proximity Notification	V	V	V	V																																																										
17PIN CONNECTOR	ALL(DTC)	V																																																													
17PIN CONNECTOR	ALL(DTC/CURR)	V		V																																																											
17PIN CONNECTOR	ECT(AT)	V																																																													
17PIN CONNECTOR	Vacuum ABS	V																																																													
17PIN CONNECTOR	Vacuum ABS/TRC/4WD	V																																																													
17PIN CONNECTOR	Hydraulic ABS/VSC/4WD	V																																																													
17PIN CONNECTOR	4WD	V																																																													
17PIN CONNECTOR	TEMS(PIEZO/SKYHOOK)	V																																																													
17PIN CONNECTOR	Air Suspension System	V																																																													
17PIN CONNECTOR	Active Suspension System	V																																																													
17PIN CONNECTOR	TRC(Traction Control System)	V																																																													
17PIN CONNECTOR	VSC(Vehicle Stability Control)	V																																																													
17PIN CONNECTOR	Cruise	V																																																													
17PIN CONNECTOR	Airbag	V																																																													
17PIN CONNECTOR	Side Airbag	V																																																													
17PIN CONNECTOR	Air Conditioner	V																																																													
17PIN CONNECTOR	4WS(4 Wheele Steering)	V																																																													
17PIN CONNECTOR	ETCS(Electronic Throttle Control System)	V																																																													

Year	System	A/T Code Reset	Inspection Mode	ECU Information Sync	ID Registration	Onboard Equalizing Charge(beta)	SOC(STATUS OF CHARGING) SET(beta)	V80 Control SET(beta)	Zero Point Calibration	Key Code Reset(ECU Relearn)	Initialization	VSC Sensor Neutral Memorization	AFS ECU Initialization(Manual)	Vehicle Height Sensor Initialization(Manual)	Vehicle Height Sensor Initialization	Injector Compensation(Bosch)	ECB Utility	VIN	Learning Value Reset	Wireless Door Lock Diagnosis Mode	Engine Throttle Learning	Recognition Camera/Target Position Memory	Recognition Camera Axis Adjust	PCS Image Record Setting	PCS Image Information Clear	Control Mode	History Clear	Battery Status Info Update	Battery Status Info Update	Grill Shutter Control Mode Switching	Evaporative System Check	Brake Line Air Bleeding(For AHB-R)	iMT Installation Information Reset	Injector Maintenance Learning Value Reset	Switch Oil Maintenance Display	Switch Battery Type	ATF Thermal Degradation Estimate Reset	DPF Rejuvenate(PM)	Check the Cylinder Compression	Learning Value Confirmation	i-ART Learning Value Reset	Glow Control Unit Inspection	Upstream Turbine Pressure Learning Value Reset	Differential Pressure Learning Value Reset	NOx Storage Catalyst Learning Value Reset	Swirl Valve Learning Value Reset	Fuel PCV Compensation Value Reset	O2 Sensor Learning Value Reset	EGR Learning Value Reset	Supply Pump Learning Value Reset	Idle Speed Adjustment	DPF History Information Reset	DPF Rejuvenation Timing Reset	Air Flow Meter Learning Value Reset	A/T Code Registration	A/T Code Reset	Starter Start Count Set	Starter Start Count Clear	Customize
16PIN CONNECTOR	TCCS(Engine/AT)															V		V	V		V										V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V			
16PIN CONNECTOR	TCCS2(Engine/AT)																																																							
16PIN CONNECTOR	Transmission(ECT/SMT/MMT)	V									V																																													
16PIN CONNECTOR	Hybrid Vehicle		V																									V	V																												
16PIN CONNECTOR	Mild Hybrid Vehicle																																																							
16PIN CONNECTOR	Hybrid Vehicle Battery					V	V	V																																																
16PIN CONNECTOR	ABS/VSC		V									V					V															V																								
16PIN CONNECTOR	ABS/VSC/ARS																																																							
16PIN CONNECTOR	Air Suspension/TEMS/AHC																																																							
16PIN CONNECTOR	Stabilizer																																																							
16PIN CONNECTOR	Electric Parking Brake																																																							
16PIN CONNECTOR	ARS(Active Rear Steer)																																																							
16PIN CONNECTOR	SRS Airbag																																																							
16PIN CONNECTOR	4WD(4 Wheel Drive)																																																							
16PIN CONNECTOR	EPS(Electric Power Steering)																																																							
16PIN CONNECTOR	Radar Cruise Control																																																							
16PIN CONNECTOR	Radar Cruise Control(HV)																																																							
16PIN CONNECTOR	Stop And Go																																																					V	V	
16PIN CONNECTOR	VGRS(Variable Gear Ratio Steering)																																																							
16PIN CONNECTOR	Immobiliser									V																																														
16PIN CONNECTOR	Precrash Safety System																																																							
16PIN CONNECTOR	IPA(Intelligent Parking Assist)																																																							
16PIN CONNECTOR	Combination meter																																																							V
16PIN CONNECTOR	EMS(Energy Management System)																																																							
16PIN CONNECTOR	Motor Generator																																																							
16PIN CONNECTOR	LKA(Lane Keeping Assist)																																																							
16PIN CONNECTOR	Active Stabilizer(Front)																																																							
16PIN CONNECTOR	Active Stabilizer(Rear)																																																							
16PIN CONNECTOR	Lane Departure Alert																					V	V	V	V	V	V																														
16PIN CONNECTOR	Front Recognition Camera																					V	V	V	V	V	V																														
16PIN CONNECTOR	Transmission Control																																																							
16PIN CONNECTOR	E-ACM(Electric Active Mount)																																																							
16PIN CONNECTOR	FCHV(Fuel Cell Hybrid Vehicle)		V																																																					
16PIN CONNECTOR	Vehicle Control																																																							
16PIN CONNECTOR	Grill Shutter																													V																											
16PIN CONNECTOR	Plug-in Control(HV)																																																							
16PIN CONNECTOR	KDSS(Kinetic Dynamic Suspension)																																																							
16PIN CONNECTOR	Tire Pressure Warning System				V																																																			
16PIN CONNECTOR	Charging Control																																																							
16PIN CONNECTOR	Starting Control																																																							
16PIN CONNECTOR	Gateway																																																							V
16PIN CONNECTOR	Body																																																							V

Year	System	A/T Code Reset	Inspection Mode	ECU Information Sync	ID Registration	Onboard Equalizing Charge(beta)	SOC(STATUS OF CHARGING) SET(beta)	V80 Control SET(beta)	Zero Point Calibration	Key Code Reset(ECU Relearn)	Initialization	VSC Sensor Neutral Memorization	AFS ECU Initialization(Manual)	Vehicle Height Sensor Initialization(Manual)	Vehicle Height Sensor Initialization	Injector Compensation(Bosch)	ECB Utility	VIN	Learning Value Reset	Wireless Door Lock Diagnosis Mode	Engine Throttle Learning	Recognition Camera/Target Position Memory	Recognition Camera Axis Adjust	PCS Image Record Setting	PCS Image Information Clear	Control Mode	History Clear	Battery Status Info Update	Battery Status Info Update	Grill Shutter Control Mode Switching	Evaporative System Check	Brake Line Air Bleeding(For AHB-R)	iMT Installation Information Reset	Injector Maintenance Learning Value Reset	Switch Oil Maintenance Display	Switch Battery Type	ATF Thermal Degradation Estimate Reset	DPF Rejuvenate(PM)	Check the Cylinder Compression	Learning Value Confirmation	i-ART Learning Value Reset	Glow Control Unit Inspection	Upstream Turbine Pressure Learning Value Reset	Differential Pressure Learning Value Reset	NOx Storage Catalyst Learning Value Reset	Swirl Valve Learning Value Reset	Fuel PCV Compensation Value Reset	O2 Sensor Learning Value Reset	EGR Learning Value Reset	Supply Pump Learning Value Reset	Idle Speed Adjustment	DPF History Information Reset	DPF Rejuvenation Timing Reset	Air Flow Meter Learning Value Reset	A/T Code Registration	A/T Code Reset	Starter Start Count Set	Starter Start Count Clear	Customize
16PIN CONNECTOR	Body No.2																																																								V
16PIN CONNECTOR	Body No.3																																																								V
16PIN CONNECTOR	Body No.4																																																								V
16PIN CONNECTOR	Body No.5																																																								
16PIN CONNECTOR	Hybrid Gateway																																																								
16PIN CONNECTOR	ECB Gateway																																																								
16PIN CONNECTOR	ECM Gateway																																																								
16PIN CONNECTOR	PM1 gateway																																																								
16PIN CONNECTOR	PM2 gateway																																																								
16PIN CONNECTOR	Accessory Gateway																																																								
16PIN CONNECTOR	Master Switch																																																								V
16PIN CONNECTOR	Combination Switch																																																								
16PIN CONNECTOR	Rear Console Switch																																																								
16PIN CONNECTOR	Air Conditioner																																																								V
16PIN CONNECTOR	Tilt And Telescopic																																																								
16PIN CONNECTOR	Driver Door(Mirror)																																																								V
16PIN CONNECTOR	Passenger Door																																																								
16PIN CONNECTOR	Rear Right Door																																																								V
16PIN CONNECTOR	Rear Left Door																																																								V
16PIN CONNECTOR	Back Door																																																								V
16PIN CONNECTOR	Driver Door Motor																																																								V
16PIN CONNECTOR	Passenger Door Motor																																																								V
16PIN CONNECTOR	Rear Right Door Motor																																																								V
16PIN CONNECTOR	Rear Left Door Motor																																																								V
16PIN CONNECTOR	Driver Seat																																																								V
16PIN CONNECTOR	Passenger Seat																																																								V
16PIN CONNECTOR	Rear Right Seat																																																								V
16PIN CONNECTOR	Rear Left Seat																																																								V
16PIN CONNECTOR	Driver Seat Switch																																																								V
16PIN CONNECTOR	Rear Right Seat Switch																																																								
16PIN CONNECTOR	Front Right Seat A/C																																																								V
16PIN CONNECTOR	Front Left Seat A/C																																																								V
16PIN CONNECTOR	Rear Right Seat A/C																																																								V
16PIN CONNECTOR	Rear Left Seat A/C																																																								V
16PIN CONNECTOR	Slide Roof																																																								V
16PIN CONNECTOR	Rain Sensor																																																								
16PIN CONNECTOR	Wiper																																																								V
16PIN CONNECTOR	Occupant Detection							V																																																	
16PIN CONNECTOR	Night View																																																								
16PIN CONNECTOR	Steering Pad(Pad Switch)																																																								
16PIN CONNECTOR	Power Source Control																																																								
16PIN CONNECTOR	Electric Power Control																																																								

Year	System	A/T Code Reset	Inspection Mode	ECU Information Sync	ID Registration	Onboard Equalizing Charge(beta)	SOC(STATUS OF CHARGING) SET(beta)	V80 Control SET(beta)	Zero Point Calibration	Key Code Reset(ECU Relearn)	Initialization	VSC Sensor Neutral Memorization	AFS ECU Initialization(Manual)	Vehicle Height Sensor Initialization(Manual)	Vehicle Height Sensor Initialization	Injector Compensation(Bosch)	ECB Utility	VIN	Learning Value Reset	Wireless Door Lock Diagnosis Mode	Engine Throttle Learning	Recognition Camera/Target Position Memory	Recognition Camera Axis Adjust	PCS Image Record Setting	PCS Image Information Clear	Control Mode	History Clear	Battery Status Info Update	Battery Status Info Update	Grill Shutter Control Mode Switching	Evaporative System Check	Brake Line Air Bleeding(For AHB-R)	iMT Installation Information Reset	Injector Maintenance Learning Value Reset	Switch Oil Maintenance Display	Switch Battery Type	ATF Thermal Degradation Estimate Reset	DPF Rejuvenate(PM)	Check the Cylinder Compression	Learning Value Confirmation	i-ART Learning Value Reset	Glow Control Unit Inspection	Upstream Turbine Pressure Learning Value Reset	Differential Pressure Learning Value Reset	NOx Storage Catalyst Learning Value Reset	Swirl Valve Learning Value Reset	Fuel PCV Compensation Value Reset	O2 Sensor Learning Value Reset	EGR Learning Value Reset	Supply Pump Learning Value Reset	Idle Speed Adjustment	DPF History Information Reset	DPF Rejuvenation Timing Reset	Air Flow Meter Learning Value Reset	A/T Code Registration	A/T Code Reset	Starter Start Count Set	Starter Start Count Clear	Customize
16PIN CONNECTOR	Entry And Start																				V																																					V
16PIN CONNECTOR	Theft Deterrent System																																																									V
16PIN CONNECTOR	Clearance Sonar																																																									V
16PIN CONNECTOR	Retractable Hard Top																																																									V
16PIN CONNECTOR	Left Seat Mirror																																																									V
16PIN CONNECTOR	Right Seat Mirror																																																									V
16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)			V									V	V	V																																											
16PIN CONNECTOR	WIL Gateway																																																									
16PIN CONNECTOR	Remote Security																																																									
16PIN CONNECTOR	Driver Seat Act Headrest																																																									
16PIN CONNECTOR	Help Net Gateway																																																									
16PIN CONNECTOR	Central Gateway										V																																															
16PIN CONNECTOR	Precrash 2										V																																															
16PIN CONNECTOR	Passenger Seat Act Headrest																																																									
16PIN CONNECTOR	Navigation System																																																									
16PIN CONNECTOR	Remote Engine Starter																																																									V
16PIN CONNECTOR	Panoramic View Monitor																																																									
16PIN CONNECTOR	Blind Spot Monitor Master																																																									
16PIN CONNECTOR	Blind Spot Monitor Slave																																																									
16PIN CONNECTOR	Active Sound Control																																																									
16PIN CONNECTOR	Multi Bus Gateway																																																									
16PIN CONNECTOR	Multi Bus Monitor1																																																									
16PIN CONNECTOR	Multi Bus Monitor2																																																									
16PIN CONNECTOR	Vehicle Proximity Notification																																																									
17PIN CONNECTOR	ALL(DTC)																																																									
17PIN CONNECTOR	ALL(DTC/CURR)																																																									
17PIN CONNECTOR	ECT(AT)																																																									
17PIN CONNECTOR	Vacuum ABS																																																									
17PIN CONNECTOR	Vacuum ABS/TRC/4WD																																																									
17PIN CONNECTOR	Hydraulic ABS/VSC/4WD																																																									
17PIN CONNECTOR	4WD																																																									
17PIN CONNECTOR	TEMS(PIEZO/SKYHOOK)																																																									
17PIN CONNECTOR	Air Suspension System																																																									
17PIN CONNECTOR	Active Suspension System																																																									
17PIN CONNECTOR	TRC(Traction Control System)																																																									
17PIN CONNECTOR	VSC(Vehicle Stability Control)																																																									
17PIN CONNECTOR	Cruise																																																									
17PIN CONNECTOR	Airbag																																																									
17PIN CONNECTOR	Side Airbag																																																									
17PIN CONNECTOR	Air Conditioner																																																									
17PIN CONNECTOR	4WS(4 Wheele Steering)																																																									
17PIN CONNECTOR	ETCS(Electronic Throttle Control System)																																																									

System1	Type1	DTC	CURR	ACT	ECUINFOR	Brake Exhaust	Write Date of Production	Write Date of Last Service	Vehicle Identification Number
Engine	Delphi EOBD	V	V	V					
Engine	Sun Tech	V	V	V					
ABS	Wanxiang	V	V	V		V			
SRS	Jinheng	V			V				
SRS	Siemens	V	V						
SRS	Bosch	V	V		V		V	V	V

Area	Vehicle	connector	system 1	system 2	DTC	CURRENT DATA	ACTUATION TEST	ECU INFORMATION
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	SYSTEM SEARCH				
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	Engine	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	TCM(Transmission Control Module)	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	Airbag	V	V	V	
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	A/C(Air Conditioning)	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	ABS/ASC	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	EPB(Electronic Parking Brake)	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	BCM+GW	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	AWD(All-Wheel Drive)	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	CSW(Composite Steering Wheel)	V	V		V
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	FECU(Front Electronic Control Unit)	V		V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	HMI(Human Machine Interface)	V	V		V
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	METER	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	THINK+	V		V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	DVD(DVD Changer)	V			
Taiwan	LUXGEN 5/S5	'2011~'2014	1.8 TURBO	KCU	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	SYSTEM SEARCH				
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	Engine	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	TCM(Transmission Control Module)	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	Airbag	V	V	V	
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	A/C(Air Conditioning)	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	ABS/ASC	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	EPB(Electronic Parking Brake)	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	BCM+GW	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	AWD(All-Wheel Drive)	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	CSW(Composite Steering Wheel)	V	V		V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	FECU(Front Electronic Control Unit)	V		V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	HMI(Human Machine Interface)	V	V		V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	METER	V	V	V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	THINK+	V		V	V
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	DVD(DVD Changer)	V			
Taiwan	LUXGEN 5/S5	'2011~'2014	2.0 TURBO	KCU	V	V	V	V
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	SYSTEM SEARCH				
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	Engine	V	V	V	V
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	TCM(Transmission Control Module)	V	V	V	V
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	Airbag	V	V	V	
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	A/C(Air Conditioning)	V	V	V	V
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	ABS/ASC	V	V	V	V
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	EPB(Electronic Parking Brake)	V	V	V	V
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	BCM+GW	V	V	V	V
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	AWD(All-Wheel Drive)	V	V	V	V
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	CSW(Composite Steering Wheel)	V	V		V
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	FECU(Front Electronic Control Unit)	V		V	V
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	HMI(Human Machine Interface)	V	V		V
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	METER	V	V	V	V

Area	Vehicle	connector	system 1	system 2	DTC	CURRENT DATA	ACTUATION TEST	ECU INFORMATION
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	THINK+	V		V	V
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	DVD(DVD Changer)	V			
Taiwan	LUXGEN U6	'2014~	2.0 TURBO	KCU	V	V	V	V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	SYSTEM SEARCH				
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	Engine	V	V	V	V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	TCM(Transmission Control Module)	V	V	V	V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	Airbag	V	V	V	
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	A/C(Air Conditioning)	V	V	V	V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	ABS/ASC	V	V	V	V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	EPB(Electronic Parking Brake)	V	V	V	V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	BCM(Body Control Module)	V	V	V	
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	AWD(All-Wheel Drive)	V	V	V	V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	CSW(Composite Steering Wheel)	V	V		V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	FECU(Front Electronic Control Unit)	V		V	V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	HMI(Human Machine Interface)	V	V		V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	METER	V	V	V	V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	THINK+	V		V	V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	DVD(DVD Changer)	V			
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	GW	V			V
Taiwan	LUXGEN 7 MPV	'2009~'2013	2.2 TURBO	KCU	V	V	V	V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	SYSTEM SEARCH				
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	Engine	V	V	V	V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	TCM(Transmission Control Module)	V	V	V	V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	Airbag	V	V	V	
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	A/C(Air Conditioning)	V	V	V	V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	ABS/ASC	V	V	V	V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	EPB(Electronic Parking Brake)	V	V	V	V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	BCM+GW	V	V	V	V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	AWD(All-Wheel Drive)	V	V	V	V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	CSW(Composite Steering Wheel)	V	V		V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	FECU(Front Electronic Control Unit)	V		V	V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	HMI(Human Machine Interface)	V	V		V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	METER	V	V	V	V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	THINK+	V		V	V
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	DVD(DVD Changer)	V			
Taiwan	LUXGEN SUV 7	'2013~'2014	2.2 TURBO	KCU	V	V	V	V

Maker	Vehicle	Model	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	Air Bleeding	Delete Key	EHCU Bleeding	Feature Coding	Input Signal Feature	Learn Key	MBFM Configuration	MBFM Feature	Odo Meter	Read IQA Code	Remote Learn	RKE Learn	RKE Learning	Service Done	Start Stop Counters	Vehicle Speed Limit	VIN Write	Write C3I Values	Write Data Identifier	Write Engine Serial Number	Write IQA Code	Write Model No	Write Parameter	Write Speed Limit	Write Speed Limiter	Write Variant Code	Write Vehicle Speed Set Point	Write VIN	Adaptives after regenerating particle filter	Adaptives after replacing cabin filter	Air damper valve programming	Automatic Relocking	Bleed Hydraulic Unit and Braking Circuits
Mahindra	SCORPIO	SLE	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V							V					
Mahindra	SCORPIO	SLE	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V	V		V																									V					
Mahindra	SCORPIO	VLX	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V							V					
Mahindra	SCORPIO	VLX	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V	V		V																									V					
Mahindra	SCORPIO	VLX	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V							V						V				V																
Mahindra	SCORPIO	VLX	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)	V	V	V	V																			V														
Mahindra	SCORPIO	LX	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V							V					
Mahindra	SCORPIO	AT	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V											V							V					
Mahindra	SCORPIO	AT	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V	V		V																									V					
Mahindra	SCORPIO	AT	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V							V						V				V																
Mahindra	SCORPIO	AT	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)	V	V	V	V																			V														
Mahindra	SCORPIO	AT	TCU (TRANSMISSION CONTROL UNIT)	V	V	V	V																																	
Mahindra	SCORPIO	EX	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	SCORPIO	2.6CRDe	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V											V							V					
Mahindra	XYLO	D2	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V							V					
Mahindra	XYLO	D2	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V								V																V					
Mahindra	XYLO	D4	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V							V					
Mahindra	XYLO	D4	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V								V																V					
Mahindra	XYLO	E4	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V											V							V					
Mahindra	XYLO	E4	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V								V																V					
Mahindra	XYLO	E4	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V																																	
Mahindra	XYLO	E6	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V											V							V					
Mahindra	XYLO	E6	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V								V																V					
Mahindra	XYLO	E8	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V											V							V					
Mahindra	XYLO	E8	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V								V																V					
Mahindra	XYLO	E8	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V																																	
Mahindra	XYLO	E8	DIS (DRIVER INFORMATION SYSTEM)	V	V	V	V																																	
Mahindra	XYLO	E8	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)	V	V	V	V																																	
Mahindra	XYLO	E9	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	XYLO	E9	IC (INSTRUMENT CLUSTER)	V	V	V	V																												V					
Mahindra	XYLO	E9	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V					V			V														V		V					
Mahindra	XYLO	E9	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V																																	
Mahindra	XYLO	E9	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)	V	V	V	V																																	
Mahindra	XYLO	E9	VCT (VOICE COMMAND TECHNOLOGY)	V	V	V	V					V			V																				V					
Mahindra	XYLO	H4	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	XYLO	H4	IC (INSTRUMENT CLUSTER)	V	V	V	V																												V					
Mahindra	XYLO	H4	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V								V																V					
Mahindra	XYLO	H4	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V																																	
Mahindra	XYLO	H6	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	XYLO	H6	IC (INSTRUMENT CLUSTER)	V	V	V	V																												V					

Maker	Vehicle	Model	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	Air Bleeding	Delete Key	EHCU Bleeding	Feature Coding	Input Signal Feature	Learn Key	MBFM Configuration	MBFM Feature	Odo Meter	Read IQA Code	Remote Learn	RKE Learn	RKE Learning	Service Done	Start Stop Counters	Vehicle Speed Limit	VIN Write	Write C3I Values	Write Data Identifier	Write Engine Serial Number	Write IQA Code	Write Model No	Write Parameter	Write Speed Limit	Write Speed Limiter	Write Variant Code	Write Vehicle Speed Set Point	Write VIN	Adaptives after regenerating particle filter	Adaptives after replacing cabin filter	Air damper valve programming	Automatic Relocking	Bleed Hydraulic Unit and Braking Circuits
Mahindra	XYLO	H6	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V					V			V													V		V					
Mahindra	XYLO	H6	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V																																
Mahindra	XYLO	H8	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	XYLO	H8	IC (INSTRUMENT CLUSTER)	V	V	V	V																											V						
Mahindra	XYLO	H8	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V					V			V													V		V						
Mahindra	XYLO	H8	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V																																	
Mahindra	XYLO	H8	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)	V	V	V	V																																	
Mahindra	XYLO	H9	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	XYLO	H9	IC (INSTRUMENT CLUSTER)	V	V	V	V																											V						
Mahindra	XYLO	H9	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V					V			V													V		V						
Mahindra	XYLO	H9	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V																																	
Mahindra	XYLO	H9	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)	V	V	V	V																																	
Mahindra	XYLO	H9	VCT (VOICE COMMAND TECHNOLOGY)	V	V	V	V					V			V																			V						
Mahindra	BOLERO	VLX	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V											V						V						
Mahindra	BOLERO	M2DiCr	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V																		V					V	V									
Mahindra	BOLERO	M2DiCr	IC (INSTRUMENT CLUSTER)	V	V	V	V																																	
Mahindra	XUV500	W4	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	XUV500	W4	IC (INSTRUMENT CLUSTER)	V	V	V	V														V																			
Mahindra	XUV500	W4	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V											V																						
Mahindra	XUV500	W4	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V																																	
Mahindra	XUV500	W4	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)	V	V	V	V																																	
Mahindra	XUV500	W6	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	XUV500	W6	IC (INSTRUMENT CLUSTER)	V	V	V	V														V																			
Mahindra	XUV500	W6	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V											V																						
Mahindra	XUV500	W6	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V																																	
Mahindra	XUV500	W6	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)	V	V	V	V																																	
Mahindra	XUV500	W6	HVAC (HEATING VENTILATION AND AIR CONDITIONING)	V	V	V	V																																	
Mahindra	XUV500	W6	IS (INFOTAINMENT SYSTEM)	V	V	V	V																							V										
Mahindra	XUV500	W6	RPAS (REVERSE PARK ASSIST SYSTEM)	V	V	V	V																																	
Mahindra	XUV500	W8	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	XUV500	W8	IC (INSTRUMENT CLUSTER)	V	V	V	V														V																			
Mahindra	XUV500	W8	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V											V																						
Mahindra	XUV500	W8	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)	V	V	V	V																																	
Mahindra	XUV500	W8	HVAC (HEATING VENTILATION AND AIR CONDITIONING)	V	V	V	V																																	
Mahindra	XUV500	W8	ITM (INTERACTIVE TORQUE MANAGEMENT SYSTEM)	V	V	V	V																																	
Mahindra	XUV500	W8	ESP (ELECTRONIC STABILITY PROGRAM)	V	V	V	V																																	
Mahindra	XUV500	W8	IS (INFOTAINMENT SYSTEM)	V	V	V	V																							V										
Mahindra	XUV500	W8	RPAS (REVERSE PARK ASSIST SYSTEM)	V	V	V	V																																	
Mahindra	GENIO	GENIO	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V				V								
Mahindra	GENIO	GENIOVX	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V				V								

Maker	Vehicle	Model	System	DTC Analysis	Data Analysis	Actuation Test	ECU Information Display	Air Bleeding	Delete Key	EHCU Bleeding	Feature Coding	Input Signal Feature	Learn Key	MBFM Configuration	MBFM Feature	Odo Meter	Read IQA Code	Remote Learn	RKE Learn	RKE Learning	Service Done	Start Stop Counters	Vehicle Speed Limit	VIN Write	Write C3I Values	Write Data Identifier	Write Engine Serial Number	Write IQA Code	Write Model No	Write Parameter	Write Speed Limit	Write Speed Limiter	Write Variant Code	Write Vehicle Speed Set Point	Write VIN	Adaptives after regenerating particle filter	Adaptives after replacing cabin filter	Air damper valve programming	Automatic Relocking	Bleed Hydraulic Unit and Braking Circuits
Mahindra	GENIO	GENIOVX	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V								V																					
Mahindra	THAR	THAR	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V											V							V					
Mahindra	MAXIMO	PASSENGER-CARRIER	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V						V					V	V						V					
Mahindra	MAXIMO	LOAD-CARRIER	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V						V				V	V	V					V	V					
Mahindra	QUANTO	C2	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	QUANTO	C2	IC (INSTRUMENT CLUSTER)	V	V	V	V																												V					
Mahindra	QUANTO	C2	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V								V																V					
Mahindra	QUANTO	C4	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	QUANTO	C4	IC (INSTRUMENT CLUSTER)	V	V	V	V																												V					
Mahindra	QUANTO	C4	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V					V			V														V		V					
Mahindra	QUANTO	C6	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	QUANTO	C6	IC (INSTRUMENT CLUSTER)	V	V	V	V																												V					
Mahindra	QUANTO	C6	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V					V			V														V		V					
Mahindra	QUANTO	C6	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V																																	
Mahindra	QUANTO	C6	DIS (DRIVER INFORMATION SYSTEM)	V	V	V	V																																	
Mahindra	QUANTO	C8	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V						V												
Mahindra	QUANTO	C8	IC (INSTRUMENT CLUSTER)	V	V	V	V																												V					
Mahindra	QUANTO	C8	MBFM (MAHINDRA BODY FUNCTION MODULE)	V	V	V	V				V					V			V														V		V					
Mahindra	QUANTO	C8	ABS (ANTI-LOCK BRAKING SYSTEM)	V	V	V	V																																	
Mahindra	QUANTO	C8	DIS (DRIVER INFORMATION SYSTEM)	V	V	V	V																																	
Mahindra	QUANTO	C8	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)	V	V	V	V																																	
Mahindra	BOLERO PIK-UP	BOLERO PIK-UP	EMS (ENGINE MANAGEMENT SYSTEM)	V	V	V	V										V					V					V	V				V		V	V					
Mahindra	SECURITY SYSTEM	EMS	ALL	V	V	V	V																																	
Mahindra	SECURITY SYSTEM	IMMOBILIZER	ALL	V	V	V	V		V				V																											
Mahindra Renault	LOGAN	LOGAN	Injection	V	V	V	V																													V	V	V		
Mahindra Renault	LOGAN	LOGAN	GAS Injection	V	V	V	V																																	
Mahindra Renault	LOGAN	LOGAN	A.B.S.	V	V	V	V																																	V
Mahindra Renault	LOGAN	LOGAN	Variable P.A.S.	V	V	V	V																																	
Mahindra Renault	LOGAN	LOGAN	UCH	V	V	V	V																																V	
Mahindra Renault	LOGAN	LOGAN	Airbag / Pretensioners	V	V	V	V																																	

Maker	Vehicle	Model	System	Cabin filter regeneration	Check target teeth	Configuration	EGR valve programming	Engine Adaptives	Enter injector codes	Erase EGR adaptives	Erase Pressure regulation adaptives	Exhaust injector circuit	Fuel Supply Prevention	Immobilizer	Lock Computer	Lock injector control	Particle filter relative pressure sensor	Pressure regularion adaptives	Read Configuration	Speed Index	Stop Fuel Supply Prevention	Unlock Computer	Vehicle parameters	Write configuration	Write Date of Last After Sales Operation
Mahindra	SCORPIO	SLE	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	SCORPIO	SLE	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	SCORPIO	VLX	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	SCORPIO	VLX	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	SCORPIO	VLX	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	SCORPIO	VLX	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)																						
Mahindra	SCORPIO	LX	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	SCORPIO	AT	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	SCORPIO	AT	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	SCORPIO	AT	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	SCORPIO	AT	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)																						
Mahindra	SCORPIO	AT	TCU (TRANSMISSION CONTROL UNIT)																						
Mahindra	SCORPIO	EX	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	SCORPIO	2.6CRDe	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XYLO	D2	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XYLO	D2	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XYLO	D4	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XYLO	D4	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XYLO	E4	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XYLO	E4	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XYLO	E4	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	XYLO	E6	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XYLO	E6	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XYLO	E8	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XYLO	E8	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XYLO	E8	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	XYLO	E8	DIS (DRIVER INFORMATION SYSTEM)																						
Mahindra	XYLO	E8	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)																						
Mahindra	XYLO	E9	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XYLO	E9	IC (INSTRUMENT CLUSTER)																						
Mahindra	XYLO	E9	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XYLO	E9	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	XYLO	E9	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)																						
Mahindra	XYLO	E9	VCT (VOICE COMMAND TECHNOLOGY)																						
Mahindra	XYLO	H4	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XYLO	H4	IC (INSTRUMENT CLUSTER)																						
Mahindra	XYLO	H4	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XYLO	H4	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	XYLO	H6	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XYLO	H6	IC (INSTRUMENT CLUSTER)																						

Maker	Vehicle	Model	System	Cabin filter regeneration	Check target teeth	Configuration	EGR valve programming	Engine Adaptives	Enter injector codes	Erase EGR adaptives	Erase Pressure regulation adaptives	Exhaust injector circuit	Fuel Supply Prevention	Immobilizer	Lock Computer	Lock injector control	Particle filter relative pressure sensor	Pressure regularion adaptives	Read Configuration	Speed Index	Stop Fuel Supply Prevention	Unlock Computer	Vehicle parameters	Write configuration	Write Date of Last After Sales Operation
Mahindra	XYLO	H6	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XYLO	H6	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	XYLO	H8	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XYLO	H8	IC (INSTRUMENT CLUSTER)																						
Mahindra	XYLO	H8	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XYLO	H8	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	XYLO	H8	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)																						
Mahindra	XYLO	H9	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XYLO	H9	IC (INSTRUMENT CLUSTER)																						
Mahindra	XYLO	H9	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XYLO	H9	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	XYLO	H9	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)																						
Mahindra	XYLO	H9	VCT (VOICE COMMAND TECHNOLOGY)																						
Mahindra	BOLERO	VLX	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	BOLERO	M2DiCr	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	BOLERO	M2DiCr	IC (INSTRUMENT CLUSTER)																						
Mahindra	XUV500	W4	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XUV500	W4	IC (INSTRUMENT CLUSTER)																						
Mahindra	XUV500	W4	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XUV500	W4	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	XUV500	W4	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)																						
Mahindra	XUV500	W6	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XUV500	W6	IC (INSTRUMENT CLUSTER)																						
Mahindra	XUV500	W6	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XUV500	W6	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	XUV500	W6	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)																						
Mahindra	XUV500	W6	HVAC (HEATING VENTILATION AND AIR CONDITIONING)																						
Mahindra	XUV500	W6	IS (INFOTAINMENT SYSTEM)																						
Mahindra	XUV500	W6	RPAS (REVERSE PARK ASSIST SYSTEM)																						
Mahindra	XUV500	W8	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	XUV500	W8	IC (INSTRUMENT CLUSTER)																						
Mahindra	XUV500	W8	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	XUV500	W8	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)																						
Mahindra	XUV500	W8	HVAC (HEATING VENTILATION AND AIR CONDITIONING)																						
Mahindra	XUV500	W8	ITM (INTERACTIVE TORQUE MANAGEMENT SYSTEM)																						
Mahindra	XUV500	W8	ESP (ELECTRONIC STABILITY PROGRAM)																						
Mahindra	XUV500	W8	IS (INFOTAINMENT SYSTEM)																						
Mahindra	XUV500	W8	RPAS (REVERSE PARK ASSIST SYSTEM)																						
Mahindra	GENIO	GENIO	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	GENIO	GENIOVX	EMS (ENGINE MANAGEMENT SYSTEM)																						

Maker	Vehicle	Model	System	Cabin filter regeneration	Check target teeth	Configuration	EGR valve programming	Engine Adaptives	Enter injector codes	Erase EGR adaptives	Erase Pressure regulation adaptives	Exhaust injector circuit	Fuel Supply Prevention	Immobilizer	Lock Computer	Lock injector control	Particle filter relative pressure sensor	Pressure regularion adaptives	Read Configuration	Speed Index	Stop Fuel Supply Prevention	Unlock Computer	Vehicle parameters	Write configuration	Write Date of Last After Sales Operation
Mahindra	GENIO	GENIOVX	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	THAR	THAR	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	MAXIMO	PASSENGER-CARRIER	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	MAXIMO	LOAD-CARRIER	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	QUANTO	C2	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	QUANTO	C2	IC (INSTRUMENT CLUSTER)																						
Mahindra	QUANTO	C2	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	QUANTO	C4	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	QUANTO	C4	IC (INSTRUMENT CLUSTER)																						
Mahindra	QUANTO	C4	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	QUANTO	C6	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	QUANTO	C6	IC (INSTRUMENT CLUSTER)																						
Mahindra	QUANTO	C6	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	QUANTO	C6	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	QUANTO	C6	DIS (DRIVER INFORMATION SYSTEM)																						
Mahindra	QUANTO	C8	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	QUANTO	C8	IC (INSTRUMENT CLUSTER)																						
Mahindra	QUANTO	C8	MBFM (MAHINDRA BODY FUNCTION MODULE)																						
Mahindra	QUANTO	C8	ABS (ANTI-LOCK BRAKING SYSTEM)																						
Mahindra	QUANTO	C8	DIS (DRIVER INFORMATION SYSTEM)																						
Mahindra	QUANTO	C8	SRS (SUPPLEMENTARY RESTRAINT SYSTEM)																						
Mahindra	BOLERO PIK-UP	BOLERO PIK-UP	EMS (ENGINE MANAGEMENT SYSTEM)																						
Mahindra	SECURITY SYSTEM	EMS	ALL																						
Mahindra	SECURITY SYSTEM	IMMOBILIZER	ALL																						
Mahindra Renault	LOGAN	LOGAN	Injection	V			V	V	V	V	V	V	V			V	V	V	V		V				
Mahindra Renault	LOGAN	LOGAN	GAS Injection																V					V	
Mahindra Renault	LOGAN	LOGAN	A.B.S.		V															V			V		V
Mahindra Renault	LOGAN	LOGAN	Variable P.A.S.																						V
Mahindra Renault	LOGAN	LOGAN	UCH			V								V											
Mahindra Renault	LOGAN	LOGAN	Airbag / Pretensioners			V									V							V			

| System 1 | DTC Analysis | Data Analysis | Actuator | ECU Information | VIN Registration | Vehicle variant registration | Read Injector Calibration Code | Replace ECM | Replace Injector | Injector calibration code | Replace catalyst converter(W/ DPF) | Replace DPF(W/ DPF) | Replace differential pressure sensor(W/ DPF) | Reset oil pressure light(W/ DPF) | DPF Regeneration(W/ DPF) | Replace MAF sensor(Reset A/F data)(W/O DPF) | Replace A/F sensor(W/O DPF) | Initialize EGR valve data | Initialize inlet throttle valve data | Initialize diesel PF data | DPF Regeneration | Replace EGR | Replace Inlet throttle valve | AT Learning Value Initialization | CVT Oil Level Adjust | CVT Learning Value Setting | Learning Value Clear | CVT G Sensor Calibration | Hydraulic Control Test | Sensor Calibration | ESP Function Setting | Airbag Setting | Keyless Start System Function | Answer-Back Setting (Buzzer Sounding Outside Vehicle) | Warning Buzzer: Portable Remote Conotroller Outside Detection-Range | Warning: Portable Remote Conotroller Battery Low | Security Alarm Setting | Answer-Back Setting | Cornering Light Setting | Warning: Parking Brake Return Operation Undone | Turn Signal Lamp Setting | Remote Folding Mirror Setting | Slope sensor initialization | Vehicle Height Sensor Initialization | ID Code Read | Immobilizer | Key | Register New Ignition Key(Fix Code) | Immobilizer Change(Register SK Code) | ECM Change(Register SKC/PWD) | ECU Reset | Reset Immobilize | Immobilizer Information | Key Register | TPS ID Registration | Aiming | Guide Me Light to Car | Guide Me Light to Home | Auto Drive Lock | Auto Drive Unlock | Shock Sensor | Foot Light | Daytime Running Light | Door Unlock | Shock Sensor Pre-warn Sensitivity | Shock Sensor Full Blast Sensitivity | Keyless Start System | Remote Controller Battery Warning | Answer-Back (Outside Buzzer) | Remote Controller Area Warning | Initialize Clutch and Transaxle | Clutch Clamp Position Control | Clutch Adjustment Control | Initialize Clutch | Initialize Transaxle | Oil Change Request Light Initialization | Oil Change Request Light | Oil Change Conditions | Starter Driving Counter Registration | Starter Driving Counter Reset |
|---|---|---

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
Incode Calculator	Incode Calculator	~2010.05				V																													
Service Manual	Reset the Oil Change Indicator(G-scan Support)						V																												
Service Manual	Oil Light Reset / Service Light Reset(Manual)							V																											
Service Manual	Throttle Body Learning								V																										
BIANTE	2.0L LF	SYSTEM SEARCH																																	
BIANTE	2.0L LF	PCM(Powertrain Control Module)								V	V	V	V	V	V	V	V	V	V	V	V														
BIANTE	2.0L LF	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V	V	V	V								
BIANTE	2.0L LF	EATC(Electronic Automatic Temperature Control)								V	V	V		V														V	V	V	V	V			
BIANTE	2.0L LF	EPS(Electronic-Controlled Power Steering)								V	V	V																					V		
BIANTE	2.0L LF	GEM(Generic Electronic Module)								V	V	V																						V	
BIANTE	2.0L LF	IC(Instrument Cluster)								V	V	V																							V
BIANTE	2.0L LF	LPSDM(Left Power Sliding Door Module)								V	V	V																							
BIANTE	2.0L LF	RCM(Restraint Control Module)								V	V	V																							
BIANTE	2.0L LF	RKE(Remote Keyless Entry)								V	V	V		V																					
BIANTE	2.0L LF	RPSDM(Right Power Sliding Door Module)								V	V	V																							
BIANTE	2.0L LF	TCM(Transmission Control Module)								V	V	V		V																					
BIANTE	2.3L L3	SYSTEM SEARCH																																	
BIANTE	2.3L L3	PCM(Powertrain Control Module)								V	V	V	V																						
BIANTE	2.3L L3	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V											
BIANTE	2.3L L3	EATC(Electronic Automatic Temperature Control)								V	V	V		V																					
BIANTE	2.3L L3	EPS(Electronic-Controlled Power Steering)								V	V	V																					V		
BIANTE	2.3L L3	GEM(Generic Electronic Module)								V	V	V																						V	
BIANTE	2.3L L3	IC(Instrument Cluster)								V	V	V																							V
BIANTE	2.3L L3	LPSDM(Left Power Sliding Door Module)								V	V	V																							
BIANTE	2.3L L3	RCM(Restraint Control Module)								V	V	V																							
BIANTE	2.3L L3	RKE(Remote Keyless Entry)								V	V	V		V																					
BIANTE	2.3L L3	RPSDM(Right Power Sliding Door Module)								V	V	V																							
BIANTE	2.3L L3	TCM(Transmission Control Module)								V	V	V		V																					
BONGOBRAWNYSPECTRON	2.0L RF_T	SYSTEM SEARCH																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	2005~							V	V	V	V																						
BONGOBRAWNYSPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	~2005							V	V	V	V																						
BONGOBRAWNYSPECTRON	2.0L RF_T	ABS(Anti-Lock Brake System)								V	V	V		V																					
BONGOBRAWNYSPECTRON	2.0L RF_T	TCM(Transmission Control Module)								V	V	V		V																					
BT-50(RANGER)	2.2 Diesel	SYSTEM SEARCH																																	
BT-50(RANGER)	2.2 Diesel	PCM(PowerTrain Control Module)								V	V	V	V	V																					
BT-50(RANGER)	2.2 Diesel	ABS(Anti-Lock Brake System)								V	V	V		V																					
BT-50(RANGER)	2.2 Diesel	ACM(Audio Control Module)								V	V	V		V																					
BT-50(RANGER)	2.2 Diesel	BCMii(Body Control Module)								V	V	V		V																					
BT-50(RANGER)	2.2 Diesel	DDM(Drivers Door Module)								V	V	V																							
BT-50(RANGER)	2.2 Diesel	FCDIM(Front Control/Display Interface Module)								V	V	V		V																					
BT-50(RANGER)	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)								V	V	V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BT-50(RANGER)	2.2 Diesel	IPC(Instrument Panel Control Module)								V	V	V		V																					
BT-50(RANGER)	2.2 Diesel	PAM(Parking Aid Module)								V	V	V																							
BT-50(RANGER)	2.2 Diesel	PDM(Passengers Door Module)								V	V	V		V																					
BT-50(RANGER)	2.2 Diesel	RCM(Restraint Control Module)								V	V	V																							
BT-50(RANGER)	2.2 Diesel	SRM(Speech Recognition Module)								V	V	V																							
BT-50(RANGER)	2.2 Diesel	TBM(Tracking And Blocking Module)								V	V	V																							
BT-50(RANGER)	2.2 Diesel	TCM(Transmission Control Module)								V		V	V	V																					
BT-50(RANGER)	2.2 Diesel	TRM(Trailer Module)								V	V	V																							
BT-50(RANGER)	2.2 Diesel	PATS(Passive anti theft system)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)								V	V	V		V																					
BT-50(RANGER)	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)								V	V	V																							
BT-50(RANGER)	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)								V	V	V																							
BT-50(RANGER)	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)								V	V	V																							
BT-50(RANGER)	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)								V	V	V	V																						
BT-50(RANGER)	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)								V	V	V																							
BT-50(RANGER)	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)								V	V	V																							
BT-50(RANGER)	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)								V	V	V																							
BT-50(RANGER)	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)																																	
BT-50(RANGER)	3.2 Diesel	SYSTEM SEARCH																																	
BT-50(RANGER)	3.2 Diesel	PCM(PowerTrain Control Module)								V	V	V	V	V																					
BT-50(RANGER)	3.2 Diesel	ABS(Anti-Lock Brake System)								V	V	V		V																					
BT-50(RANGER)	3.2 Diesel	ACM(Audio Control Module)								V	V	V		V																					
BT-50(RANGER)	3.2 Diesel	BCMii(Body Control Module)								V	V	V		V																					
BT-50(RANGER)	3.2 Diesel	DDM(Drivers Door Module)								V	V	V																							
BT-50(RANGER)	3.2 Diesel	FCDIM(Front Control/Display Interface Module)								V	V	V		V																					
BT-50(RANGER)	3.2 Diesel	HVAC(Heating Ventilation Air Conditioning)								V	V	V		V																					
BT-50(RANGER)	3.2 Diesel	IPC(Instrument Panel Control Module)								V	V	V		V																					
BT-50(RANGER)	3.2 Diesel	PAM(Parking Aid Module)								V	V	V																							
BT-50(RANGER)	3.2 Diesel	PDM(Passengers Door Module)								V	V	V		V																					
BT-50(RANGER)	3.2 Diesel	RCM(Restraint Control Module)								V	V	V																							
BT-50(RANGER)	3.2 Diesel	SRM(Speech Recognition Module)								V	V	V																							
BT-50(RANGER)	3.2 Diesel	TBM(Tracking And Blocking Module)								V	V	V																							
BT-50(RANGER)	3.2 Diesel	TCM(Transmission Control Module)								V		V	V	V																					
BT-50(RANGER)	3.2 Diesel	TRM(Trailer Module)								V	V	V																							
BT-50(RANGER)	3.2 Diesel	PATS(Passive anti theft system)																																	
BT-50(RANGER)	2.3 Gasoline	PCM(Powertrain Control Module)								V	V	V	V	V																					
BT-50(RANGER)	2.3 Gasoline	ABS(Anti-Lock Brake System)								V	V	V		V																					
BT-50(RANGER)	2.3 Gasoline	GEM(Generic Electronic Module)								V	V	V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BT-50(RANGER)	2.3 Gasoline	IC(Instrument Cluster)								V	V	V		V																					
BT-50(RANGER)	2.3 Gasoline	OCSM(Occupant Classification System Module)								V	V	V																							
BT-50(RANGER)	2.3 Gasoline	4x4(4x4 Control Module)								V	V	V																							
BT-50(RANGER)	2.3 Gasoline	RCM(Restraint Control Module)								V	V	V		V																					
BT-50(RANGER)	2.3 Gasoline	SDARS(Satellite Digital Audio Receiver System)								V	V	V																							
BT-50(RANGER)	2.3 Gasoline	TCM(Transmission Control Module)								V		V	V	V																					
BT-50(RANGER)	2.5 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	2.5 Gasoline	PCM(PowerTrain Control Module)								V	V	V	V	V																					
BT-50(RANGER)	2.5 Gasoline	ABS(Anti-Lock Brake System)								V	V	V		V																					
BT-50(RANGER)	2.5 Gasoline	ACM(Audio Control Module)								V	V	V		V																					
BT-50(RANGER)	2.5 Gasoline	BCMii(Body Control Module)								V	V	V		V																					
BT-50(RANGER)	2.5 Gasoline	DDM(Drivers Door Module)								V	V	V																							
BT-50(RANGER)	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)								V	V	V		V																					
BT-50(RANGER)	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)								V	V	V		V																					
BT-50(RANGER)	2.5 Gasoline	IPC(Instrument Panel Control Module)								V	V	V		V																					
BT-50(RANGER)	2.5 Gasoline	PAM(Parking Aid Module)								V	V	V																							
BT-50(RANGER)	2.5 Gasoline	PDM(Passengers Door Module)								V	V	V		V																					
BT-50(RANGER)	2.5 Gasoline	RCM(Restraint Control Module)								V	V	V																							
BT-50(RANGER)	2.5 Gasoline	SRM(Speech Recognition Module)								V	V	V																							
BT-50(RANGER)	2.5 Gasoline	TBM(Tracking And Blocking Module)								V	V	V																							
BT-50(RANGER)	2.5 Gasoline	TCM(Transmission Control Module)								V		V	V	V																					
BT-50(RANGER)	2.5 Gasoline	TRM(Trailer Module)								V	V	V																							
BT-50(RANGER)	2.5 Gasoline	PATS(Passive anti theft system)																																	
BT-50(RANGER)	3.0 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	3.0 Gasoline	PCM(Powertrain Control Module)								V	V	V	V	V																					
BT-50(RANGER)	3.0 Gasoline	ABS(Anti-Lock Brake System)								V	V	V		V																					
BT-50(RANGER)	3.0 Gasoline	GEM(Generic Electronic Module)								V	V	V																							
BT-50(RANGER)	3.0 Gasoline	IC(Instrument Cluster)								V	V	V		V																					
BT-50(RANGER)	3.0 Gasoline	OCSM(Occupant Classification System Module)								V	V	V																							
BT-50(RANGER)	3.0 Gasoline	4x4(4x4 Control Module)								V	V	V																							
BT-50(RANGER)	3.0 Gasoline	RCM(Restraint Control Module)								V	V	V		V																					
BT-50(RANGER)	3.0 Gasoline	SDARS(Satellite Digital Audio Receiver System)								V	V	V																							
BT-50(RANGER)	3.0 Gasoline	TCM(Transmission Control Module)								V		V	V	V																					
BT-50(RANGER)	4.0 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	4.0 Gasoline	PCM(Powertrain Control Module)								V	V	V	V	V																					
BT-50(RANGER)	4.0 Gasoline	ABS(Anti-Lock Brake System)								V	V	V		V																					
BT-50(RANGER)	4.0 Gasoline	GEM/SJB(Generic Electronic Module/Smart Junction Box)								V	V	V																							
BT-50(RANGER)	4.0 Gasoline	IC(Instrument Cluster)								V	V	V		V																					
BT-50(RANGER)	4.0 Gasoline	OCSM(Occupant Classification System Module)								V	V	V																							
BT-50(RANGER)	4.0 Gasoline	4x4(4x4 Control Module)								V	V	V																							
BT-50(RANGER)	4.0 Gasoline	RCM(Restraint Control Module)								V	V	V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BT-50(RANGER)	4.0 Gasoline	SDARS(Satellite Digital Audio Receiver System)								V	V	V																							
BT-50(RANGER)	4.0 Gasoline	TCM(Transmission Control Module)								V		V	V	V																					
CX-3	1.5L S5	SYSTEM SEARCH																																	
CX-3	1.5L S5	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
CX-3	1.5L S5	TCM(Transmission Control Module)								V	V	V																							
CX-3	1.5L S5	4x4(4x4 Control Module)								V	V	V																							
CX-3	1.5L S5	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
CX-3	1.5L S5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)								V	V	V																							
CX-3	1.5L S5	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
CX-3	1.5L S5	EPS(Electronic-Controlled Power Steering)								V	V	V																							
CX-3	1.5L S5	ESU(Electric Supply Unit)								V	V																								
CX-3	1.5L S5	IC(Instrument Cluster)								V		V		V																					
CX-3	1.5L S5	RCM(Restraint Control Module)								V	V	V																							
CX-3	1.5L S5	BSM(Blind Spot Monitoring)								V		V		V																					
CX-3	1.5L S5	BCM(Body Control Module)								V		V		V																					
CX-3	1.5L S5	CMU(Connectivity Master Unit)								V	V																								
CX-3	1.5L S5	FSC(Forward Sensing Camera)								V	V	V																							
CX-3	1.5L S5	SSU(Smart Start Unit)								V		V		V																					
CX-3	1.5L S5	SCBS(Smart City Brake Support)								V	V	V																							
CX-3	1.5L S5	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)								V	V	V																							
CX-3	2.0L PE	SYSTEM SEARCH																																	
CX-3	2.0L PE	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
CX-3	2.0L PE	TCM(Transmission Control Module)								V	V	V																							
CX-3	2.0L PE	4x4(4x4 Control Module)								V	V	V																							
CX-3	2.0L PE	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
CX-3	2.0L PE	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)								V	V	V																							
CX-3	2.0L PE	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
CX-3	2.0L PE	EPS(Electronic-Controlled Power Steering)								V	V	V																							
CX-3	2.0L PE	ESU(Electric Supply Unit)								V	V																								
CX-3	2.0L PE	IC(Instrument Cluster)								V		V		V																					
CX-3	2.0L PE	RCM(Restraint Control Module)								V	V	V																							
CX-3	2.0L PE	BSM(Blind Spot Monitoring)								V		V		V																					
CX-3	2.0L PE	BCM(Body Control Module)								V		V		V																					
CX-3	2.0L PE	CMU(Connectivity Master Unit)								V	V																								
CX-3	2.0L PE	FSC(Forward Sensing Camera)								V	V	V																							
CX-3	2.0L PE	SSU(Smart Start Unit)								V		V		V																					
CX-3	2.0L PE	SCBS(Smart City Brake Support)								V	V	V																							
CX-3	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)								V	V	V																							
CX-5	2.0L PE	SYSTEM SEARCH																																	
CX-5	2.0L PE	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
CX-5	2.0L PE	TCM(Transmission Control Module)								V	V	V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
CX-5	2.0L PE	4x4(4x4 Control Module)								V	V	V																							
CX-5	2.0L PE	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
CX-5	2.0L PE	ACU(Audio Control Unit)								V	V	V																							
CX-5	2.0L PE	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
CX-5	2.0L PE	AM(Amplifier Module)								V	V	V		V																					
CX-5	2.0L PE	AFS(Adaptive Front Lighting System)								V	V	V																							
CX-5	2.0L PE	DSM(Drivers Seat Module)								V		V																							
CX-5	2.0L PE	DCDC(DC to DC Converter Control Module)								V	V	V																							
CX-5	2.0L PE	FSC(Forward Sensing Camera)								V	V	V																							
CX-5	2.0L PE	SCBS(Smart City Brake Support)								V	V	V																							
CX-5	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)								V	V	V																							
CX-5	2.0L PE	EPS(Electronic-Controlled Power Steering)								V	V	V																							
CX-5	2.0L PE	IC(Instrument Cluster)								V		V		V																					
CX-5	2.0L PE	RVM(Rear Vehicle Monitoring)								V		V		V																					
CX-5	2.0L PE	RCM(Restraint Control Module)								V	V	V																							
CX-5	2.0L PE	SSU(Smart Start Unit)								V		V		V																					
CX-5	2.0L PE	BSM(Blind Spot Monitoring)								V		V		V																					
CX-5	2.0L PE	F_BCM(Front Body Control Module)								V		V		V																					
CX-5	2.0L PE	R_BCM(Rear Body Control Module)								V	V	V		V																					
CX-5	2.2L SH	SYSTEM SEARCH																																	
CX-5	2.2L SH	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
CX-5	2.2L SH	TCM(Transmission Control Module)								V	V	V																							
CX-5	2.2L SH	4x4(4x4 Control Module)								V	V	V																							
CX-5	2.2L SH	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
CX-5	2.2L SH	ACU(Audio Control Unit)								V	V	V																							
CX-5	2.2L SH	CMU(Connectivity Master Unit)								V	V																								
CX-5	2.2L SH	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
CX-5	2.2L SH	AM(Amplifier Module)								V	V	V		V																					
CX-5	2.2L SH	AFS(Adaptive Front Lighting System)								V	V	V																							
CX-5	2.2L SH	DSM(Drivers Seat Module)								V		V																							
CX-5	2.2L SH	DCDC(DC to DC Converter Control Module)								V	V	V																							
CX-5	2.2L SH	FSC(Forward Sensing Camera)								V	V	V																							
CX-5	2.2L SH	SCBS(Smart City Brake Support)								V	V	V																							
CX-5	2.2L SH	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)								V	V	V																							
CX-5	2.2L SH	EPB(Electonic Parking Brake)								V	V	V																							
CX-5	2.2L SH	EPS(Electronic-Controlled Power Steering)								V	V	V																							
CX-5	2.2L SH	IC(Instrument Cluster)								V		V		V																					
CX-5	2.2L SH	RVM(Rear Vehicle Monitoring)								V		V		V																					
CX-5	2.2L SH	RCM(Restraint Control Module)								V	V	V																							
CX-5	2.2L SH	SSU(Smart Start Unit)								V		V		V																					
CX-5	2.2L SH	BSM(Blind Spot Monitoring)								V		V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
CX-5	2.2L SH	F_BCM(Front Body Control Module)								V		V		V																					
CX-5	2.2L SH	R_BCM(Rear Body Control Module)								V	V	V		V																					
CX-5	2.5L PY	SYSTEM SEARCH																																	
CX-5	2.5L PY	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
CX-5	2.5L PY	TCM(Transmission Control Module)								V	V	V																							
CX-5	2.5L PY	4x4(4x4 Control Module)								V	V	V																							
CX-5	2.5L PY	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
CX-5	2.5L PY	AM(Amplifier Module)								V	V	V		V																					
CX-5	2.5L PY	DSM(Drivers Seat Module)								V		V																							
CX-5	2.5L PY	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
CX-5	2.5L PY	EPB(Electonic Parking Brake)								V	V	V																							
CX-5	2.5L PY	EPS(Electronic-Controlled Power Steering)								V	V	V																							
CX-5	2.5L PY	IC(Instrument Cluster)								V		V		V																					
CX-5	2.5L PY	RCM(Restraint Control Module)								V	V	V																							
CX-5	2.5L PY	AFS(Adaptive Front Lighting System)								V	V	V																							
CX-5	2.5L PY	FSC(Forward Sensing Camera)								V	V	V																							
CX-5	2.5L PY	SSU(Smart Start Unit)								V		V		V																					
CX-5	2.5L PY	BSM(Blind Spot Monitoring)-JAPAN								V		V		V																					
CX-5	2.5L PY	BSML(Blind Spot Monitoring Left)								V		V		V																					
CX-5	2.5L PY	BSMR(Blind Spot Monitoring Right)								V		V		V																					
CX-5	2.5L PY	F_BCM(Front Body Control Module)								V		V		V																					
CX-5	2.5L PY	R_BCM(Rear Body Control Module)								V	V	V		V																					
CX-5	2.5L PY	SCBS(Smart City Brake Support)								V	V	V																							
CX-5	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)								V	V	V																							
CX-5	2.5L PY	ACU(Audio Control Unit)								V	V	V																							
CX-5	2.5L PY	CMU(Connectivity Master Unit)								V	V																								
CX-7	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
CX-7	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)								V	V	V	V	V																					
CX-7	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
CX-7	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)								V		V		V									V	V											
CX-7	2.2L R2_T (Diesel)	EATC(Electronic Automatic Temperature Control)								V	V	V		V														V	V	V	V	V			
CX-7	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)								V		V																							
CX-7	2.2L R2_T (Diesel)	GEM(Generic Electronic Module)								V		V																							
CX-7	2.2L R2_T (Diesel)	IC(Instrument Cluster)								V		V		V																					
CX-7	2.2L R2_T (Diesel)	RCM(Restraint Control Module)								V		V																							
CX-7	2.2L R2_T (Diesel)	MID(Multi-Information Display)								V		V																							
CX-7	2.2L R2_T (Diesel)	SCR CU(Selective Catalytic Reduction)								V		V																							
CX-7	2.2L R2_T (Diesel)	RKE(Remote Keyless Entry)								V		V		V																					
CX-7	2.2L R2_T (Diesel)	RVM(Rear Vehicle Monitoring)								V		V		V																					
CX-7	2.2L R2_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)								V	V	V																							
CX-7	2.3L L3_T	SYSTEM SEARCH																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
CX-7	2.3L L3_T	PCM(Powertrain Control Module)								V		V	V	V																					
CX-7	2.3L L3_T	PATS(Passive anti theft system)-Beta																																	
CX-7	2.3L L3_T	ABS(Anti-Lock Brake System)								V		V		V									V	V											
CX-7	2.3L L3_T	EATC(Electronic Automatic Temperature Control)								V	V	V		V														V	V	V	V	V			
CX-7	2.3L L3_T	AM(Amplifier Module)								V	V	V																							
CX-7	2.3L L3_T	GEM(Generic Electronic Module)								V		V																							
CX-7	2.3L L3_T	IC(Instrument Cluster)								V		V																							
CX-7	2.3L L3_T	RCM(Restraint Control Module)								V		V																							
CX-7	2.3L L3_T	TCM(Transmission Control Module)								V		V	V																						
CX-7	2.3L L3_T	ACU(Audio Control Unit)								V	V	V																							
CX-7	2.3L L3_T	4*4(4*4 Control Module)								V																									
CX-7	2.3L L3_T	MID(Multi-Information Display)								V		V																							
CX-7	2.3L L3_T	RKE(Remote Keyless Entry)								V		V		V																					
CX-7	2.3L L3_T	LCM(Lighting Control Module)								V	V	V																							
CX-7	2.3L L3_T	RVM(Rear Vehicle Monitoring)								V		V		V																					
CX-7	2.5L L5	SYSTEM SEARCH																																	
CX-7	2.5L L5	PCM(Powertrain Control Module)								V		V	V	V																					
CX-7	2.5L L5	PATS(Passive anti theft system)-Beta																																	
CX-7	2.5L L5	TCM(Transmission Control Module)								V	V	V	V	V																					
CX-7	2.5L L5	ABS(Anti-Lock Brake System)								V		V		V									V	V											
CX-7	2.5L L5	RCM(Restraint Control Module)								V		V																							
CX-7	2.5L L5	GEM(Generic Electronic Module)								V		V																							
CX-7	2.5L L5	IC(Instrument Cluster)								V		V		V																					
CX-7	2.5L L5	MID(Multi-Information Display)-Beta Test								V		V																							
CX-7	2.5L L5	EATC(Electronic Automatic Temperature Control)								V	V	V		V														V	V	V	V	V			
CX-7	2.5L L5	ACU(Audio Control Unit)								V	V	V																							
CX-7	2.5L L5	ICCM(Intelligent Cruise Control Module)								V		V																							
CX-7	2.5L L5	RKE(Remote Keyless Entry)								V		V		V																					
CX-7	2.5L L5	RVM(Rear Vehicle Monitoring)								V		V		V																					
CX-7	2.5L L5	LCM(Lighting Control Module)								V	V	V																							
CX-9	3.7L CA	SYSTEM SEARCH																																	
CX-9	3.7L CA	PCM(Powertrain Control Module)								V		V	V																						
CX-9	3.7L CA	PATS(Passive anti theft system)-Beta																																	
CX-9	3.7L CA	ABS(Anti-Lock Brake System)								V		V																							
CX-9	3.7L CA	4WD(Four Wheel Drive)-Beta Test								V		V																							
CX-9	3.7L CA	DSM(Drivers Seat Module)								V		V																							
CX-9	3.7L CA	GEM(Generic Electronic Module)								V		V																							
CX-9	3.7L CA	IC(Instrument Cluster) - Without Tire Pressure Monitor								V		V																							
CX-9	3.7L CA	IC(Instrument Cluster) - With Tire Pressure Monitor-Beta Test								V		V																							
CX-9	3.7L CA	LCM(Lighting Control Module)-Beta Test								V	V	V																							
CX-9	3.7L CA	LTM(Liftgate/Trunk Module)-Beta Test								V		V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
CX-9	3.7L CA	RCM(Restraint Control Module) - Except USA								V		V																							
CX-9	3.7L CA	RCM(Restraint Control Module) - USA-Beta Test								V		V																							
CX-9	3.7L CA	RKE(Remote Keyless Entry)-Beta Test								V		V																							
CX-9	3.7L CA	TCM(Transmission Control Module)								V		V	V																						
CX-9	3.7L CA	BSML(Blind Spot Monitoring Left)-Beta Test								V		V																							
CX-9	3.7L CA	BSMR(Blind Spot Monitoring Right)-Beta Test								V		V																							
CX-9	3.5L CY-Beta Test	SYSTEM SEARCH																																	
CX-9	3.5L CY-Beta Test	PCM(Powertrain Control Module)								V		V	V																						
CX-9	3.5L CY-Beta Test	PATS(Passive anti theft system)-Beta																																	
CX-9	3.5L CY-Beta Test	ABS(Anti-Lock Brake System)								V		V																							
CX-9	3.5L CY-Beta Test	4WD(Four Wheel Drive)								V		V																							
CX-9	3.5L CY-Beta Test	GEM(Generic Electronic Module)								V		V																							
CX-9	3.5L CY-Beta Test	IC(Instrument Cluster) - Without Tire Pressure Monitor								V		V																							
CX-9	3.5L CY-Beta Test	IC(Instrument Cluster) - With Tire Pressure Monitor								V		V																							
CX-9	3.5L CY-Beta Test	LTM(Liftgate/Trunk Module)								V		V																							
CX-9	3.5L CY-Beta Test	RCM(Restraint Control Module) - USA								V		V																							
CX-9	3.5L CY-Beta Test	RKE(Remote Keyless Entry)								V		V																							
CX-9	3.5L CY-Beta Test	TCM(Transmission Control Module)								V		V	V																						
DEMIOVERISAMAZDA2	1.3L ZJ	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.3L ZJ	PCM(Powertrain Control Module)								V	V	V	V																						
DEMIOVERISAMAZDA2	1.3L ZJ	PATS(Passive anti theft system)-Beta																																	
DEMIOVERISAMAZDA2	1.3L ZJ	ABS(Anti-Lock Brake System)								V	V	V		V									V												
DEMIOVERISAMAZDA2	1.3L ZJ	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V		V																					
DEMIOVERISAMAZDA2	1.3L ZJ	IC(Instrument Cluster)								V	V	V																							
DEMIOVERISAMAZDA2	1.3L ZJ	RCM(Restraint Control Module)								V	V	V																							
DEMIOVERISAMAZDA2	1.3L ZJ	EPS(Electronic-Controlled Power Steering)								V	V	V																							
DEMIOVERISAMAZDA2	1.3L ZJ	RKE(Remote Keyless Entry)								V	V	V		V																					
DEMIOVERISAMAZDA2	1.3L P3	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.3L P3	PCM(Powertrain Control Module)								V	V	V	V	V																					
DEMIOVERISAMAZDA2	1.3L P3	TCM(Transmission Control Module)								V	V	V		V																					
DEMIOVERISAMAZDA2	1.3L P3	ABS(Anti-Lock Brake System)								V	V	V		V										V			V								
DEMIOVERISAMAZDA2	1.3L P3	BCM(Body Control Module)								V		V		V																					
DEMIOVERISAMAZDA2	1.3L P3	EATC(Electronic Automatic Temperature Control)								V	V	V		V														V	V	V	V	V			
DEMIOVERISAMAZDA2	1.3L P3	EPS(Electronic-Controlled Power Steering)								V	V	V																							
DEMIOVERISAMAZDA2	1.3L P3	FSC(Forward Sensing Camera)								V	V	V																							
DEMIOVERISAMAZDA2	1.3L P3	IC(Instrument Cluster)								V	V	V		V																					
DEMIOVERISAMAZDA2	1.3L P3	RCM(Restraint Control Module)								V	V	V																							
DEMIOVERISAMAZDA2	1.3L P3	SSU(Smart Start Unit)								V		V		V																					
DEMIOVERISAMAZDA2	1.3L P3	SCBS(Smart City Brake Support)								V	V	V																							
DEMIOVERISAMAZDA2	1.3L P3	ALM(Auto Leveling Module)								V	V	V																							
DEMIOVERISAMAZDA2	1.3L P3	BSM(Blind Spot Monitoring)								V		V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
DEMIOVERISAMAZDA2	1.3L P3	CMU(Connectivity Master Unit)								V	V																								
DEMIOVERISAMAZDA2	1.3L P3	ESU(Electric Supply Unit)								V	V																								
DEMIOVERISAMAZDA2	1.5L ZY	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L ZY	PCM(Powertrain Control Module)								V	V	V	V																						
DEMIOVERISAMAZDA2	1.5L ZY	PATS(Passive anti theft system)-Beta																																	
DEMIOVERISAMAZDA2	1.5L ZY	ABS(Anti-Lock Brake System)								V	V	V		V									V												
DEMIOVERISAMAZDA2	1.5L ZY	IC(Instrument Cluster)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L ZY	EPS(Electronic-Controlled Power Steering)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L ZY	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V		V																					
DEMIOVERISAMAZDA2	1.5L ZY	RCM(Restraint Control Module)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L ZY	RKE(Remote Keyless Entry)	With SKE							V	V	V		V																					
DEMIOVERISAMAZDA2	1.5L ZY	RKE(Remote Keyless Entry)	Without SKE							V	V	V		V																					
DEMIOVERISAMAZDA2	1.5L ZY	VSM(Vehicle Security Module)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L P5	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L P5	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
DEMIOVERISAMAZDA2	1.5L P5	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
DEMIOVERISAMAZDA2	1.5L P5	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
DEMIOVERISAMAZDA2	1.5L P5	EPS(Electronic-Controlled Power Steering)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L P5	IC(Instrument Cluster)								V		V		V																					
DEMIOVERISAMAZDA2	1.5L P5	RCM(Restraint Control Module)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L P5	TCM(Transmission Control Module)								V	V	V		V																					
DEMIOVERISAMAZDA2	1.5L P5	BSM(Blind Spot Monitoring)								V		V		V																					
DEMIOVERISAMAZDA2	1.5L P5	BCM(Body Control Module)								V		V		V																					
DEMIOVERISAMAZDA2	1.5L P5	FSC(Forward Sensing Camera)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L P5	SSU(Smart Start Unit)								V		V		V																					
DEMIOVERISAMAZDA2	1.5L P5	SCBS(Smart City Brake Support)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L P5	ALM(Auto Leveling Module)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L P5	CMU(Connectivity Master Unit)								V	V																								
DEMIOVERISAMAZDA2	1.5L P5	ESU(Electric Supply Unit)								V	V																								
DEMIOVERISAMAZDA2	1.5L S5	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L S5	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
DEMIOVERISAMAZDA2	1.5L S5	TCM(Transmission Control Module)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L S5	4x4(4x4 Control Module)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L S5	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
DEMIOVERISAMAZDA2	1.5L S5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L S5	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
DEMIOVERISAMAZDA2	1.5L S5	EPS(Electronic-Controlled Power Steering)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L S5	ESU(Electric Supply Unit)								V	V																								
DEMIOVERISAMAZDA2	1.5L S5	IC(Instrument Cluster)								V		V		V																					
DEMIOVERISAMAZDA2	1.5L S5	RCM(Restraint Control Module)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L S5	BSM(Blind Spot Monitoring)								V		V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
DEMIOVERISAMAZDA2	1.5L S5	BCM(Body Control Module)								V		V		V																					
DEMIOVERISAMAZDA2	1.5L S5	CMU(Connectivity Master Unit)								V	V																								
DEMIOVERISAMAZDA2	1.5L S5	FSC(Forward Sensing Camera)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L S5	SSU(Smart Start Unit)								V		V		V																					
DEMIOVERISAMAZDA2	1.5L S5	SCBS(Smart City Brake Support)								V	V	V																							
DEMIOVERISAMAZDA2	1.5L S5	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)								V	V	V																							
DEMIOVERISAMAZDA2	1.6L Y6-Beta	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	PCM(Powertrain Control Module)					V			V	V	V	V																						
DEMIOVERISAMAZDA2	1.6L Y6-Beta	PATS(Passive anti theft system)-Beta																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	ABS(Anti-Lock Brake System)								V	V	V																							
DEMIOVERISAMAZDA2	1.6L Y6-Beta	IC(Instrument Cluster)								V	V	V																							
DEMIOVERISAMAZDA2	1.6L Y6-Beta	EPS(Electronic-Controlled Power Steering)								V	V	V																							
DEMIOVERISAMAZDA2	1.6L Y6-Beta	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V		V																					
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RCM(Restraint Control Module)								V	V	V																							
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RKE(Remote Keyless Entry)	With SKE							V	V	V																							
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RKE(Remote Keyless Entry)	Without SKE							V	V	V																							
DEMIOVERISAMAZDA2	1.6L Y6-Beta	VSM(Vehicle Security Module)								V	V	V																							
AXELAMAZDA3	1.5L ZY	SYSTEM SEARCH																																	
AXELAMAZDA3	1.5L ZY	PCM(Powertrain Control Module)								V		V	V	V																					
AXELAMAZDA3	1.5L ZY	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
AXELAMAZDA3	1.5L ZY	EPS(Electronic-Controlled Power Steering)								V	V	V																					V		
AXELAMAZDA3	1.5L ZY	RCM(Restraint Control Module)								V	V	V																							
AXELAMAZDA3	1.5L ZY	IC(Instrument Cluster)								V	V	V																							V
AXELAMAZDA3	1.5L ZY	GEM(Generic Electronic Module)								V	V	V																						V	
AXELAMAZDA3	1.5L ZY	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	1.6L Y6	SYSTEM SEARCH																																	
AXELAMAZDA3	1.6L Y6	PCM(Powertrain Control Module)								V	V	V	V	V																					
AXELAMAZDA3	1.6L Y6	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V											
AXELAMAZDA3	1.6L Y6	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V																						V	
AXELAMAZDA3	1.6L Y6	EATC(Electronic Automatic Temperature Control)								V	V	V																V	V	V	V	V			
AXELAMAZDA3	1.6L Y6	EPS(Electronic-Controlled Power Steering)								V	V	V																					V		
AXELAMAZDA3	1.6L Y6	FACM(Fuel Additive Control Module)								V	V	V																							
AXELAMAZDA3	1.6L Y6	IC(Instrument Cluster)								V	V	V																							V
AXELAMAZDA3	1.6L Y6	RCM(Restraint Control Module)								V	V	V																							
AXELAMAZDA3	1.6L Y6	RKE(Remote Keyless Entry)								V	V	V		V																					
AXELAMAZDA3	1.6L Y6	BSML(Blind Spot Monitoring Left)								V		V																							
AXELAMAZDA3	1.6L Y6	BSMR(Blind Spot Monitoring Right)								V		V																							
AXELAMAZDA3	1.6L Y6	AFS(Adaptive Front Lighting System)								V		V																							
AXELAMAZDA3	1.6L Y6	MID(Multi-Information Display)								V		V																							
AXELAMAZDA3	1.6L Y6	ACU(Audio Control Unit)								V	V	V																							
AXELAMAZDA3	1.6L Y6	PATS(Passive anti theft system)-Beta																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
AXELAMAZDA3	1.6L Z6	SYSTEM SEARCH																																	
AXELAMAZDA3	1.6L Z6	PCM(Powertrain Control Module)								V		V	V	V																					
AXELAMAZDA3	1.6L Z6	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V											
AXELAMAZDA3	1.6L Z6	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V																							
AXELAMAZDA3	1.6L Z6	EATC(Electronic Automatic Temperature Control)								V	V	V																V	V	V	V	V			
AXELAMAZDA3	1.6L Z6	EPS(Electronic-Controlled Power Steering)								V	V	V																							
AXELAMAZDA3	1.6L Z6	IC(Instrument Cluster)								V	V	V																							V
AXELAMAZDA3	1.6L Z6	GEM(Generic Electronic Module)								V	V	V																						V	
AXELAMAZDA3	1.6L Z6	MID(Multi-Information Display)								V		V																							
AXELAMAZDA3	1.6L Z6	RCM(Restraint Control Module)								V	V	V																							
AXELAMAZDA3	1.6L Z6	ACU(Audio Control Unit)								V	V	V																							
AXELAMAZDA3	1.6L Z6	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.0L LF	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L LF	PCM(Powertrain Control Module)								V		V	V	V																					
AXELAMAZDA3	2.0L LF	TCM(Transmission Control Module)								V	V	V		V																					
AXELAMAZDA3	2.0L LF	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
AXELAMAZDA3	2.0L LF	EATC(Electronic Automatic Temperature Control)								V	V	V		V														V	V	V	V	V			
AXELAMAZDA3	2.0L LF	EPS(Electronic-Controlled Power Steering)								V	V	V																					V		
AXELAMAZDA3	2.0L LF	RCM(Restraint Control Module)								V	V	V																							
AXELAMAZDA3	2.0L LF	IC(Instrument Cluster)								V	V	V																							V
AXELAMAZDA3	2.0L LF	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V																							
AXELAMAZDA3	2.0L LF	MID(Multi-Information Display)								V		V																							
AXELAMAZDA3	2.0L LF	ACU(Audio Control Unit)								V	V	V																							
AXELAMAZDA3	2.0L LF	GEM(Generic Electronic Module)								V	V	V																						V	
AXELAMAZDA3	2.0L LF	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.0L PE	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L PE	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
AXELAMAZDA3	2.0L PE	TCM(Transmission Control Module)								V	V	V																							
AXELAMAZDA3	2.0L PE	4x4(4x4 Control Module)								V	V	V																							
AXELAMAZDA3	2.0L PE	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
AXELAMAZDA3	2.0L PE	ACU(Audio Control Unit)								V	V	V																							
AXELAMAZDA3	2.0L PE	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
AXELAMAZDA3	2.0L PE	AM(Amplifier Module)								V	V	V		V																					
AXELAMAZDA3	2.0L PE	AFS(Adaptive Front Lighting System)								V	V	V																							
AXELAMAZDA3	2.0L PE	DSM(Drivers Seat Module)								V		V																							
AXELAMAZDA3	2.0L PE	DCDC(DC to DC Converter Control Module)								V	V	V																							
AXELAMAZDA3	2.0L PE	FSC(Forward Sensing Camera)								V	V	V																							
AXELAMAZDA3	2.0L PE	SCBS(Smart City Brake Support)								V	V	V																							
AXELAMAZDA3	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)								V	V	V																							
AXELAMAZDA3	2.0L PE	EPS(Electronic-Controlled Power Steering)								V	V	V																							
AXELAMAZDA3	2.0L PE	IC(Instrument Cluster)								V		V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
AXELAMAZDA3	2.0L PE	RVM(Rear Vehicle Monitoring)								V		V		V																					
AXELAMAZDA3	2.0L PE	RCM(Restraint Control Module)								V	V	V																							
AXELAMAZDA3	2.0L PE	SSU(Smart Start Unit)								V		V		V																					
AXELAMAZDA3	2.0L PE	F_BCM(Front Body Control Module)								V		V		V																					
AXELAMAZDA3	2.0L PE	R_BCM(Rear Body Control Module)								V	V	V		V																					
AXELAMAZDA3	2.0L PE	CMU(Connectivity Master Unit)								V	V																								
AXELAMAZDA3	2.3L L3_T	SYSTEM SEARCH																																	
AXELAMAZDA3	2.3L L3_T	PCM(Powertrain Control Module)								V		V	V	V																					
AXELAMAZDA3	2.3L L3_T	TCM(Transmission Control Module)								V	V	V	V	V																					
AXELAMAZDA3	2.3L L3_T	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
AXELAMAZDA3	2.3L L3_T	EPS(Electronic-Controlled Power Steering)								V	V	V																					V		
AXELAMAZDA3	2.3L L3_T	EATC(Electronic Automatic Temperature Control)								V	V	V		V														V	V	V	V	V			
AXELAMAZDA3	2.3L L3_T	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V																						V	
AXELAMAZDA3	2.3L L3_T	IC(Instrument Cluster)								V	V	V																							V
AXELAMAZDA3	2.3L L3_T	RCM(Restraint Control Module)								V	V	V																							
AXELAMAZDA3	2.3L L3_T	AFS(Adaptive Front Lighting System)								V		V																							
AXELAMAZDA3	2.3L L3_T	MID(Multi-Information Display)								V		V																							
AXELAMAZDA3	2.3L L3_T	ACU(Audio Control Unit)								V	V	V																							
AXELAMAZDA3	2.3L L3_T	LCM(Lighting Control Module)								V	V	V																							
AXELAMAZDA3	2.3L L3_T	RKE(Remote Keyless Entry)								V	V	V																							
AXELAMAZDA3	2.3L L3_T	TPM(Tire Pressure Monitor)								V	V	V																							
AXELAMAZDA3	2.3L L3_T	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.5L L5	SYSTEM SEARCH																																	
AXELAMAZDA3	2.5L L5	PCM(Powertrain Control Module)								V		V	V	V																					
AXELAMAZDA3	2.5L L5	TCM(Transmission Control Module)								V	V	V		V																					
AXELAMAZDA3	2.5L L5	ABS(Anti-Lock Brake System)								V	V	V										V	V	V			V								
AXELAMAZDA3	2.5L L5	EPS(Electronic-Controlled Power Steering)								V	V	V																					V		
AXELAMAZDA3	2.5L L5	EATC(Electronic Automatic Temperature Control)								V	V	V																V	V	V	V	V			
AXELAMAZDA3	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V																							
AXELAMAZDA3	2.5L L5	IC(Instrument Cluster)								V	V	V																							
AXELAMAZDA3	2.5L L5	RCM(Restraint Control Module)								V	V	V																							
AXELAMAZDA3	2.5L L5	MID(Multi-Information Display)								V		V																							
AXELAMAZDA3	2.5L L5	ACU(Audio Control Unit)								V	V	V																							
AXELAMAZDA3	2.5L L5	AFS(Adaptive Front Lighting System)								V		V																							
AXELAMAZDA3	2.5L L5	RKE(Remote Keyless Entry)								V	V	V																							
AXELAMAZDA3	2.5L PY	SYSTEM SEARCH																																	
AXELAMAZDA3	2.5L PY	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
AXELAMAZDA3	2.5L PY	TCM(Transmission Control Module)								V	V	V																							
AXELAMAZDA3	2.5L PY	4x4(4x4 Control Module)								V	V	V																							
AXELAMAZDA3	2.5L PY	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
AXELAMAZDA3	2.5L PY	AM(Amplifier Module)								V	V	V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
AXELAMAZDA3	2.5L PY	DSM(Drivers Seat Module)								V		V																							
AXELAMAZDA3	2.5L PY	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
AXELAMAZDA3	2.5L PY	EPB(Electonic Parking Brake)								V	V	V																							
AXELAMAZDA3	2.5L PY	EPS(Electronic-Controlled Power Steering)								V	V	V																							
AXELAMAZDA3	2.5L PY	IC(Instrument Cluster)								V		V		V																					
AXELAMAZDA3	2.5L PY	RCM(Restraint Control Module)								V	V	V																							
AXELAMAZDA3	2.5L PY	AFS(Adaptive Front Lighting System)								V	V	V																							
AXELAMAZDA3	2.5L PY	FSC(Forward Sensing Camera)								V	V	V																							
AXELAMAZDA3	2.5L PY	SSU(Smart Start Unit)								V		V		V																					
AXELAMAZDA3	2.5L PY	F_BCM(Front Body Control Module)								V		V		V																					
AXELAMAZDA3	2.5L PY	R_BCM(Rear Body Control Module)								V	V	V		V																					
AXELAMAZDA3	2.5L PY	SCBS(Smart City Brake Support)								V	V	V																							
AXELAMAZDA3	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)								V	V	V																							
AXELAMAZDA3	2.5L PY	ACU(Audio Control Unit)								V	V	V																							
AXELAMAZDA3	2.5L PY	CMU(Connectivity Master Unit)								V	V																								
AXELAMAZDA3	2.5L PY	BSML(Blind Spot Monitoring Left)								V		V		V																					
AXELAMAZDA3	2.5L PY	BSMR(Blind Spot Monitoring Right)								V		V		V																					
AXELAMAZDA3	2.0L RF_T (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	PCM(Powertrain Control Module)								V	V	V	V	V																					
AXELAMAZDA3	2.0L RF_T (Diesel)	ABS(Anti-Lock Brake System)								V		V																							
AXELAMAZDA3	2.0L RF_T (Diesel)	RCM(Restraint Control Module)								V		V																							
AXELAMAZDA3	2.0L RF_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)								V	V	V	V	V																					
AXELAMAZDA3	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)								V	V	V										V	V	V			V								
AXELAMAZDA3	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)								V	V	V																					V		
AXELAMAZDA3	2.2L R2_T (Diesel)	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V																							
AXELAMAZDA3	2.2L R2_T (Diesel)	RCM(Restraint Control Module)								V	V	V																							
AXELAMAZDA3	2.2L R2_T (Diesel)	IC(Instrument Cluster)								V	V	V																							
AXELAMAZDA3	2.2L R2_T (Diesel)	MID(Multi-Information Display)								V		V																							
AXELAMAZDA3	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.2L SH (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.2L SH (Diesel)	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
AXELAMAZDA3	2.2L SH (Diesel)	TCM(Transmission Control Module)								V	V	V																							
AXELAMAZDA3	2.2L SH (Diesel)	4x4(4x4 Control Module)								V	V	V																							
AXELAMAZDA3	2.2L SH (Diesel)	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
AXELAMAZDA3	2.2L SH (Diesel)	ACU(Audio Control Unit)								V	V	V																							
AXELAMAZDA3	2.2L SH (Diesel)	CMU(Connectivity Master Unit)								V	V																								
AXELAMAZDA3	2.2L SH (Diesel)	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
AXELAMAZDA3	2.2L SH (Diesel)	AM(Amplifier Module)								V	V	V		V																					
AXELAMAZDA3	2.2L SH (Diesel)	AFS(Adaptive Front Lighting System)								V	V	V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
AXELAMAZDA3	2.2L SH (Diesel)	DSM(Drivers Seat Module)								V		V																							
AXELAMAZDA3	2.2L SH (Diesel)	DCDC(DC to DC Converter Control Module)								V	V	V																							
AXELAMAZDA3	2.2L SH (Diesel)	FSC(Forward Sensing Camera)								V	V	V																							
AXELAMAZDA3	2.2L SH (Diesel)	SCBS(Smart City Brake Support)								V	V	V																							
AXELAMAZDA3	2.2L SH (Diesel)	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)								V	V	V																							
AXELAMAZDA3	2.2L SH (Diesel)	EPB(Electonic Parking Brake)								V	V	V																							
AXELAMAZDA3	2.2L SH (Diesel)	EPS(Electronic-Controlled Power Steering)								V	V	V																							
AXELAMAZDA3	2.2L SH (Diesel)	IC(Instrument Cluster)								V		V		V																					
AXELAMAZDA3	2.2L SH (Diesel)	RVM(Rear Vehicle Monitoring)								V		V		V																					
AXELAMAZDA3	2.2L SH (Diesel)	RCM(Restraint Control Module)								V	V	V																							
AXELAMAZDA3	2.2L SH (Diesel)	SSU(Smart Start Unit)								V		V		V																					
AXELAMAZDA3	2.2L SH (Diesel)	F_BCM(Front Body Control Module)								V		V		V																					
AXELAMAZDA3	2.2L SH (Diesel)	R_BCM(Rear Body Control Module)								V	V	V		V																					
PREMACYMAZDA5	1.6L Y6 (BETA)	SYSTEM SEARCH																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	PCM(Powertrain Control Module)								V	V	V	V																						
PREMACYMAZDA5	1.6L Y6 (BETA)	ABS(Anti-Lock Brake System)								V	V	V		V										V	V	V	V								
PREMACYMAZDA5	1.6L Y6 (BETA)	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V		V																					
PREMACYMAZDA5	1.6L Y6 (BETA)	EATC(Electronic Automatic Temperature Control)								V	V	V																V	V	V	V	V			
PREMACYMAZDA5	1.6L Y6 (BETA)	EPS(Electronic-Controlled Power Steering)								V	V	V																					V		
PREMACYMAZDA5	1.6L Y6 (BETA)	IC(Instrument Cluster)								V	V	V		V																					
PREMACYMAZDA5	1.6L Y6 (BETA)	LPSDM(Left Power Sliding Module)								V	V	V																							
PREMACYMAZDA5	1.6L Y6 (BETA)	RCM(Restraint Control Module)								V	V	V																							
PREMACYMAZDA5	1.6L Y6 (BETA)	RKE(Remote Keyless Entry)								V	V	V		V																					
PREMACYMAZDA5	1.6L Y6 (BETA)	RPSDM(Right Power Sliding Module)								V	V	V																							
PREMACYMAZDA5	1.6L Y6 (BETA)	ACU(Audio Control Unit)								V	V	V																							
PREMACYMAZDA5	1.8L (BETA)	2005	SYSTEM SEARCH																																
PREMACYMAZDA5	1.8L (BETA)	2005	PCM(Powertrain Control Module)-MT							V	V	V	V																						
PREMACYMAZDA5	1.8L (BETA)	2005	ABS(Anti-Lock Brake System)							V	V	V		V																					
PREMACYMAZDA5	1.8L (BETA)	2005	EATC(Electronic Automatic Temperature Control)							V	V	V		V														V	V	V	V	V			
PREMACYMAZDA5	1.8L (BETA)	2005	EPS(Electronic-Controlled Power Steering)							V	V	V																					V		
PREMACYMAZDA5	1.8L (BETA)	2005	GEM(Generic Electronic Module)							V	V	V																							
PREMACYMAZDA5	1.8L (BETA)	2005	RCM(Restraint Control Module)							V	V	V																							
PREMACYMAZDA5	1.8L (BETA)	2005	IC(Instrument Cluster)							V	V	V																							V
PREMACYMAZDA5	1.8L (BETA)	2005	LPSDM(Left Power Sliding Module)							V	V	V																							
PREMACYMAZDA5	1.8L (BETA)	2005	RPSDM(Right Power Sliding Module)							V	V	V																							
PREMACYMAZDA5	1.8L (BETA)	2005	RKE(Remote Keyless Entry)							V	V	V		V																					
PREMACYMAZDA5	1.8L (BETA)	2005	PATS(Passive anti theft system)-Beta																																
PREMACYMAZDA5	2.0L LF	2005	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2005	PCM(Powertrain Control Module)	ALL						V	V	V	V																						
PREMACYMAZDA5	2.0L LF	2005	PCM(Powertrain Control Module)	AT						V	V	V	V																						
PREMACYMAZDA5	2.0L LF	2005	ABS(Anti-Lock Brake System)							V	V	V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
PREMACYMAZDA5	2.0L LF	2005	EPS(Electronic-Controlled Power Steering)							V	V	V																					V		
PREMACYMAZDA5	2.0L LF	2005	GEM(Generic Electronic Module)							V	V	V																							
PREMACYMAZDA5	2.0L LF	2005	RCM(Restraint Control Module)							V	V	V																							
PREMACYMAZDA5	2.0L LF	2005	EATC(Electronic Automatic Temperature Control)							V	V	V		V														V	V	V	V	V			
PREMACYMAZDA5	2.0L LF	2005	IC(Instrument Cluster)							V	V	V																							V
PREMACYMAZDA5	2.0L LF	2005	RKE(Remote Keyless Entry)							V	V	V		V																					
PREMACYMAZDA5	2.0L LF	2005	PATS(Passive anti theft system)-Beta																																
PREMACYMAZDA5	2.0L LF	2007	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2007	PCM(Powertrain Control Module)							V	V	V	V	V																					
PREMACYMAZDA5	2.0L LF	2007	ABS(Anti-Lock Brake System)							V	V	V		V																					
PREMACYMAZDA5	2.0L LF	2007	EPS(Electronic-Controlled Power Steering)							V	V	V																					V		
PREMACYMAZDA5	2.0L LF	2007	GEM(Generic Electronic Module)							V	V	V																							
PREMACYMAZDA5	2.0L LF	2007	RCM(Restraint Control Module)							V	V	V																							
PREMACYMAZDA5	2.0L LF	2007	EATC(Electronic Automatic Temperature Control)							V	V	V		V														V	V	V	V	V			
PREMACYMAZDA5	2.0L LF	2007	IC(Instrument Cluster)							V	V	V																							V
PREMACYMAZDA5	2.0L LF	2007	RKE(Remote Keyless Entry)							V	V	V		V																					
PREMACYMAZDA5	2.0L LF	2007	PATS(Passive anti theft system)-Beta																																
PREMACYMAZDA5	2.0L LF	2010~	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2010~	PCM(Powertrain Control Module)							V		V	V	V	V	V	V	V		V	V														
PREMACYMAZDA5	2.0L LF	2010~	ABS(Anti-Lock Brake System)							V	V	V		V										V	V	V	V								
PREMACYMAZDA5	2.0L LF	2010~	BCM/GEM(Body Control Module/Generic Electronic Module)							V	V	V		V																					
PREMACYMAZDA5	2.0L LF	2010~	EATC(Electronic Automatic Temperature Control)							V	V	V																V	V	V	V	V			
PREMACYMAZDA5	2.0L LF	2010~	EPS(Electronic-Controlled Power Steering)							V	V	V																					V		
PREMACYMAZDA5	2.0L LF	2010~	IC(Instrument Cluster)							V	V	V		V																					
PREMACYMAZDA5	2.0L LF	2010~	RKE(Remote Keyless Entry)							V	V	V		V																					
PREMACYMAZDA5	2.0L LF	2010~	LPSDM(Left Power Sliding Module)							V	V	V																							
PREMACYMAZDA5	2.0L LF	2010~	RCM(Restraint Control Module)							V	V	V																							
PREMACYMAZDA5	2.0L LF	2010~	RPSDM(Right Power Sliding Module)							V	V	V																							
PREMACYMAZDA5	2.0L LF	2010~	TCM(Transmission Control Module)							V	V	V		V																					
PREMACYMAZDA5	2.0L RF_T (Diesel)	SYSTEM SEARCH																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	PCM(Powertrain Control Module)								V	V	V	V	V																					
PREMACYMAZDA5	2.0L RF_T (Diesel)	TCM(Transmission Control Module)								V	V	V	V	V																					
PREMACYMAZDA5	2.0L RF_T (Diesel)	ABS(Anti-Lock Brake System)								V	V	V		V																					
PREMACYMAZDA5	2.0L RF_T (Diesel)	EATC(Electronic Automatic Temperature Control)								V	V	V		V														V	V	V	V	V			
PREMACYMAZDA5	2.0L RF_T (Diesel)	GEM(Generic Electronic Module)								V	V	V																							
PREMACYMAZDA5	2.0L RF_T (Diesel)	IC(Instrument Cluster)								V	V	V																							V
PREMACYMAZDA5	2.0L RF_T (Diesel)	RCM(Restraint Control Module)								V	V	V																							
PREMACYMAZDA5	2.0L RF_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)								V	V	V																							
PREMACYMAZDA5	2.0L RF_T (Diesel)	RKE(Remote Keyless Entry)								V	V	V		V																					
PREMACYMAZDA5	2.0L RF_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
PREMACYMAZDA5	2.3L L3	SYSTEM SEARCH																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
PREMACYMAZDA5	2.3L L3	PCM(Powertrain Control Module)								V		V	V	V																					
PREMACYMAZDA5	2.3L L3	ABS(Anti-Lock Brake System)								V	V	V		V																					
PREMACYMAZDA5	2.3L L3	EATC(Electronic Automatic Temperature Control)								V	V	V		V														V	V	V	V	V			
PREMACYMAZDA5	2.3L L3	EPS(Electronic-Controlled Power Steering)								V	V	V																					V		
PREMACYMAZDA5	2.3L L3	GEM(Generic Electronic Module)								V	V	V																							
PREMACYMAZDA5	2.3L L3	IC(Instrument Cluster)								V	V	V																							V
PREMACYMAZDA5	2.3L L3	RCM(Restraint Control Module)								V	V	V																							
PREMACYMAZDA5	2.3L L3	TPM(Tire Pressure Monitor)								V	V	V		V																					
PREMACYMAZDA5	2.5L L5	SYSTEM SEARCH																																	
PREMACYMAZDA5	2.5L L5	PCM(Powertrain Control Module)								V		V	V	V																					
PREMACYMAZDA5	2.5L L5	TCM(Transmission Control Module)								V	V	V		V																					
PREMACYMAZDA5	2.5L L5	ABS(Anti-Lock Brake System)								V	V	V												V											
PREMACYMAZDA5	2.5L L5	EPS(Electronic-Controlled Power Steering)								V	V	V																					V		
PREMACYMAZDA5	2.5L L5	RCM(Restraint Control Module)								V	V	V																							
PREMACYMAZDA5	2.5L L5	IC(Instrument Cluster)								V	V	V																							
PREMACYMAZDA5	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V		V																					
PREMACYMAZDA5	2.5L L5	LPSDM(Left Power Sliding Module)								V	V	V																							
PREMACYMAZDA5	2.5L L5	RPSDM(Right Power Sliding Module)								V	V	V																							
PREMACYMAZDA5	2.5L L5	EATC(Electronic Automatic Temperature Control)								V	V	V																V	V	V	V	V			
PREMACYMAZDA5	2.5L L5	AFS(Adaptive Front Lighting System)								V		V																							
PREMACYMAZDA5	2.5L L5	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	1.8L L8	SYSTEM SEARCH																																	
ATENZAMAZDA6	1.8L L8	PCM(Powertrain Control Module)								V	V	V	V	V																					
ATENZAMAZDA6	1.8L L8	TCM(Transmission Control Module)								V		V	V	V																					
ATENZAMAZDA6	1.8L L8	ABS(Anti-Lock Brake System)								V	V	V		V																					
ATENZAMAZDA6	1.8L L8	GEM(Generic Electronic Module)								V	V	V																							
ATENZAMAZDA6	1.8L L8	IC(Instrument Cluster)								V	V	V																							
ATENZAMAZDA6	1.8L L8	LHID(Left High Intensity Discharge Lamp)								V	V	V		V																					
ATENZAMAZDA6	1.8L L8	RCM(Restraint Control Module)								V	V	V																							
ATENZAMAZDA6	1.8L L8	RHID(Right High Intensity Discharge Lamp)								V	V	V		V																					
ATENZAMAZDA6	1.8L L8	RKE(Remote Keyless Entry)								V	V	V		V																					
ATENZAMAZDA6	1.8L L8	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.0L PE	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.0L PE	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
ATENZAMAZDA6	2.0L PE	TCM(Transmission Control Module)								V	V	V																							
ATENZAMAZDA6	2.0L PE	4x4(4x4 Control Module)								V	V	V																							
ATENZAMAZDA6	2.0L PE	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
ATENZAMAZDA6	2.0L PE	ACU(Audio Control Unit)								V	V	V																							
ATENZAMAZDA6	2.0L PE	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
ATENZAMAZDA6	2.0L PE	EPB(Electonic Parking Brake)								V	V	V																							
ATENZAMAZDA6	2.0L PE	AM(Amplifier Module)								V	V	V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
ATENZAMAZDA6	2.0L PE	AFS(Adaptive Front Lighting System)								V	V	V																							
ATENZAMAZDA6	2.0L PE	DSM(Drivers Seat Module)								V		V																							
ATENZAMAZDA6	2.0L PE	DCDC(DC to DC Converter Control Module)								V	V	V																							
ATENZAMAZDA6	2.0L PE	FSC(Forward Sensing Camera)								V	V	V																							
ATENZAMAZDA6	2.0L PE	SCBS(Smart City Brake Support)								V	V	V																							
ATENZAMAZDA6	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)								V	V	V																							
ATENZAMAZDA6	2.0L PE	EPS(Electronic-Controlled Power Steering)								V	V	V																							
ATENZAMAZDA6	2.0L PE	IC(Instrument Cluster)								V		V		V																					
ATENZAMAZDA6	2.0L PE	RVM(Rear Vehicle Monitoring)								V		V		V																					
ATENZAMAZDA6	2.0L PE	RCM(Restraint Control Module)								V	V	V																							
ATENZAMAZDA6	2.0L PE	SSU(Smart Start Unit)								V		V		V																					
ATENZAMAZDA6	2.0L PE	F_BCM(Front Body Control Module)								V		V		V																					
ATENZAMAZDA6	2.0L PE	R_BCM(Rear Body Control Module)								V	V	V		V																					
ATENZAMAZDA6	2.0L PE	CMU(Connectivity Master Unit)								V	V																								
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	PCM(Powertrain Control Module)							V		V	V	V																					
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	TCM(Transmission Control Module)							V		V	V	V																					
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	ABS(Anti-Lock Brake System)							V		V		V																					
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	RCM(Restraint Control Module)							V		V																							
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.0L LF	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.0L LF	PCM(Powertrain Control Module)								V		V	V	V																					
ATENZAMAZDA6	2.0L LF	ABS(Anti-Lock Brake System)								V	V	V		V													V								
ATENZAMAZDA6	2.0L LF	ACU(Audio Control Unit)								V	V	V																							
ATENZAMAZDA6	2.0L LF	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V		V																					
ATENZAMAZDA6	2.0L LF	EATC(Electronic Automatic Temperature Control)								V	V	V																V	V	V	V	V			
ATENZAMAZDA6	2.0L LF	EPS(Electronic-Controlled Power Steering)								V	V	V																							
ATENZAMAZDA6	2.0L LF	GEM(Generic Electronic Module)								V	V	V																							
ATENZAMAZDA6	2.0L LF	IC(Instrument Cluster)								V	V	V																							
ATENZAMAZDA6	2.0L LF	LCM(Lighting Control Module)								V	V	V																							
ATENZAMAZDA6	2.0L LF	RCM(Restraint Control Module)								V	V	V																							
ATENZAMAZDA6	2.0L LF	RHID(Right High Intensity Discharge Lamp)								V	V	V		V																					
ATENZAMAZDA6	2.0L LF	TCM(Transmission Control Module)								V	V	V		V																					
ATENZAMAZDA6	2.0L LF	LHID(Left High Intensity Discharge Lamp)								V	V	V		V																					
ATENZAMAZDA6	2.0L LF	RKE(Remote Keyless Entry)								V	V	V		V																					
ATENZAMAZDA6	2.0L LF	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.3L L3	2.3L	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3L	PCM(Powertrain Control Module)							V		V	V	V																					
ATENZAMAZDA6	2.3L L3	2.3L	TCM(Transmission Control Module)							V	V	V	V	V																					
ATENZAMAZDA6	2.3L L3	2.3L	ABS(Anti-Lock Brake System)							V	V	V		V																					
ATENZAMAZDA6	2.3L L3	2.3L	IC(Instrument Cluster)							V	V	V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
ATENZAMAZDA6	2.3L L3	2.3L	GEM(Generic Electronic Module)							V	V	V																							
ATENZAMAZDA6	2.3L L3	2.3L	RHID(Right High Intensity Discharge Lamp)							V	V	V		V																					
ATENZAMAZDA6	2.3L L3	2.3L	LHID(Left High Intensity Discharge Lamp)							V	V	V		V																					
ATENZAMAZDA6	2.3L L3	2.3L	RCM(Restraint Control Module)							V	V	V																							
ATENZAMAZDA6	2.3L L3	2.3L	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	PCM(Powertrain Control Module)							V		V	V	V																					
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	TCM(Transmission Control Module)							V		V	V	V																					
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	ABS(Anti-Lock Brake System)							V		V		V																					
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	RCM(Restraint Control Module)							V		V																							
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	PCM(Powertrain Control Module)							V		V	V	V																					
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	TCM(Transmission Control Module)							V		V	V	V																					
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	ABS(Anti-Lock Brake System)							V		V		V																					
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	RCM(Restraint Control Module)							V		V																							
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.3L L3_T	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.3L L3_T	PCM(Powertrain Control Module)								V		V	V	V																					
ATENZAMAZDA6	2.3L L3_T	TCM(Transmission Control Module)								V	V	V	V	V																					
ATENZAMAZDA6	2.3L L3_T	ABS(Anti-Lock Brake System)								V	V	V		V																					
ATENZAMAZDA6	2.3L L3_T	IC(Instrument Cluster)								V	V	V																							
ATENZAMAZDA6	2.3L L3_T	LHID(Left High Intensity Discharge Lamp)								V	V	V		V																					
ATENZAMAZDA6	2.3L L3_T	RHID(Right High Intensity Discharge Lamp)								V	V	V		V																					
ATENZAMAZDA6	2.3L L3_T	RCM(Restraint Control Module)								V	V	V																							
ATENZAMAZDA6	2.3L L3_T	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	PCM(Powertrain Control Module)							V		V	V	V																					
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	TCM(Transmission Control Module)							V		V	V	V																					
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	ABS(Anti-Lock Brake System)							V		V		V																					
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	RCM(Restraint Control Module)							V		V																							
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.5L L5	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.5L L5	PCM(Powertrain Control Module)								V		V	V	V																					
ATENZAMAZDA6	2.5L L5	TCM(Transmission Control Module)								V	V	V		V																					
ATENZAMAZDA6	2.5L L5	ABS(Anti-Lock Brake System)								V	V	V		V													V								
ATENZAMAZDA6	2.5L L5	EPS(Electronic-Controlled Power Steering)								V	V	V																							
ATENZAMAZDA6	2.5L L5	RCM(Restraint Control Module)								V	V	V																							
ATENZAMAZDA6	2.5L L5	IC(Instrument Cluster)								V	V	V																							
ATENZAMAZDA6	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V		V																					
ATENZAMAZDA6	2.5L L5	EATC(Electronic Automatic Temperature Control)								V	V	V																V	V	V	V	V			

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
ATENZAMAZDA6	2.5L L5	AFS(Adaptive Front Lighting System)								V		V																							
ATENZAMAZDA6	2.5L L5	LCM(Lighting Control Module)								V	V	V																							
ATENZAMAZDA6	2.5L L5	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.5L PY	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.5L PY	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
ATENZAMAZDA6	2.5L PY	TCM(Transmission Control Module)								V	V	V																							
ATENZAMAZDA6	2.5L PY	4x4(4x4 Control Module)								V	V	V																							
ATENZAMAZDA6	2.5L PY	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
ATENZAMAZDA6	2.5L PY	AM(Amplifier Module)								V	V	V		V																					
ATENZAMAZDA6	2.5L PY	BSML(Blind Spot Monitoring Left)								V		V		V																					
ATENZAMAZDA6	2.5L PY	BSMR(Blind Spot Monitoring Right)								V		V		V																					
ATENZAMAZDA6	2.5L PY	DSM(Drivers Seat Module)								V		V																							
ATENZAMAZDA6	2.5L PY	DCDC(DC to DC Converter Control Module)								V	V	V																							
ATENZAMAZDA6	2.5L PY	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
ATENZAMAZDA6	2.5L PY	EPB(Electonic Parking Brake)								V	V	V																							
ATENZAMAZDA6	2.5L PY	EPS(Electronic-Controlled Power Steering)								V	V	V																							
ATENZAMAZDA6	2.5L PY	IC(Instrument Cluster)								V		V		V																					
ATENZAMAZDA6	2.5L PY	RCM(Restraint Control Module)								V	V	V																							
ATENZAMAZDA6	2.5L PY	AFS(Adaptive Front Lighting System)								V	V	V																							
ATENZAMAZDA6	2.5L PY	FSC(Forward Sensing Camera)								V	V	V																							
ATENZAMAZDA6	2.5L PY	SSU(Smart Start Unit)								V		V		V																					
ATENZAMAZDA6	2.5L PY	F_BCM(Front Body Control Module)								V		V		V																					
ATENZAMAZDA6	2.5L PY	R_BCM(Rear Body Control Module)								V	V	V		V																					
ATENZAMAZDA6	2.5L PY	SCBS(Smart City Brake Support)								V	V	V																							
ATENZAMAZDA6	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)								V	V	V																							
ATENZAMAZDA6	2.5L PY	ACU(Audio Control Unit)								V	V	V																							
ATENZAMAZDA6	2.5L PY	CMU(Connectivity Master Unit)								V	V																								
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	PCM(Powertrain Control Module)							V	V	V	V	V																					
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	ABS(Anti-Lock Brake System)							V	V	V																							
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	FFH(Fuel Fired Coolant Heating Module)							V	V	V																							
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	IC(Instrument Cluster)							V	V	V																							
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	LHID(Left High Intensity Discharge Lamp)							V	V	V		V																					
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	RHID(Right High Intensity Discharge Lamp)							V	V	V		V																					
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	RCM(Restraint Control Module)							V	V	V																							
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	PCM(Powertrain Control Module)							V	V	V	V	V																					
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	ABS(Anti-Lock Brake System)							V	V	V		V													V								
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	ACU(Audio Control Unit)							V	V	V																							
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	BCM/GEM(Body Control Module/Generic Electronic Module)							V	V	V		V																					
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	GEM(Generic Electronic Module)							V	V	V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	EATC(Electronic Automatic Temperature Control)							V	V	V																V	V	V	V	V			
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	IC(Instrument Cluster)							V	V	V		V																					
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	EPS(Electronic-Controlled Power Steering)							V	V	V																							
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	FFH(Fuel Fired Coolant Heating Module)							V	V	V																							
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	RCM(Restraint Control Module)							V	V	V																							
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	LCM(Lighting Control Module)							V	V	V																							
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	RVM(Rear Vehicle Monitoring)							V		V		V																					
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)								V	V	V	V																						
ATENZAMAZDA6	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)								V	V	V		V													V								
ATENZAMAZDA6	2.2L R2_T (Diesel)	ACU(Audio Control Unit)								V	V	V																							
ATENZAMAZDA6	2.2L R2_T (Diesel)	BCM/GEM(Body Control Module/Generic Electronic Module)								V	V	V		V																					
ATENZAMAZDA6	2.2L R2_T (Diesel)	EATC(Electronic Automatic Temperature Control)								V	V	V																V	V	V	V	V			
ATENZAMAZDA6	2.2L R2_T (Diesel)	IC(Instrument Cluster)								V	V	V		V																					
ATENZAMAZDA6	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)								V	V	V																							
ATENZAMAZDA6	2.2L R2_T (Diesel)	RCM(Restraint Control Module)								V	V	V																							
ATENZAMAZDA6	2.2L R2_T (Diesel)	LCM(Lighting Control Module)								V	V	V																							
ATENZAMAZDA6	2.2L R2_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)								V	V	V																							
ATENZAMAZDA6	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.2L SH (Diesel)	PCM(Powertrain Control Module)						V		V	V	V	V	V																					
ATENZAMAZDA6	2.2L SH (Diesel)	TCM(Transmission Control Module)								V	V	V																							
ATENZAMAZDA6	2.2L SH (Diesel)	4x4(4x4 Control Module)								V	V	V																							
ATENZAMAZDA6	2.2L SH (Diesel)	ABS(Anti-Lock Brake System)								V	V	V		V								V	V	V			V								
ATENZAMAZDA6	2.2L SH (Diesel)	AM(Amplifier Module)								V	V	V		V																					
ATENZAMAZDA6	2.2L SH (Diesel)	CMU(Connectivity Master Unit)								V	V																								
ATENZAMAZDA6	2.2L SH (Diesel)	EATC(Electronic Automatic Temperature Control)								V	V	V																V		V	V				
ATENZAMAZDA6	2.2L SH (Diesel)	AFS(Adaptive Front Lighting System)								V	V	V																							
ATENZAMAZDA6	2.2L SH (Diesel)	DSM(Drivers Seat Module)								V		V																							
ATENZAMAZDA6	2.2L SH (Diesel)	DCDC(DC to DC Converter Control Module)								V	V	V																							
ATENZAMAZDA6	2.2L SH (Diesel)	FSC(Forward Sensing Camera)								V	V	V																							
ATENZAMAZDA6	2.2L SH (Diesel)	SCBS(Smart City Brake Support)								V	V	V																							
ATENZAMAZDA6	2.2L SH (Diesel)	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)								V	V	V																							
ATENZAMAZDA6	2.2L SH (Diesel)	EPB(Electonic Parking Brake)								V	V	V																							
ATENZAMAZDA6	2.2L SH (Diesel)	EPS(Electronic-Controlled Power Steering)								V	V	V																							
ATENZAMAZDA6	2.2L SH (Diesel)	IC(Instrument Cluster)								V		V		V																					
ATENZAMAZDA6	2.2L SH (Diesel)	RVM(Rear Vehicle Monitoring)								V		V		V																					
ATENZAMAZDA6	2.2L SH (Diesel)	RCM(Restraint Control Module)								V	V	V																							
ATENZAMAZDA6	2.2L SH (Diesel)	SSU(Smart Start Unit)								V		V		V																					
ATENZAMAZDA6	2.2L SH (Diesel)	F_BCM(Front Body Control Module)								V		V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
ATENZAMAZDA6	2.2L SH (Diesel)	R_BCM(Rear Body Control Module)								V	V	V		V																					
ATENZAMAZDA6	2.2L SH (Diesel)	BSM(Blind Spot Monitoring)								V		V		V																					
ATENZAMAZDA6	2.2L SH (Diesel)	PSM(Parking Sensor Module)								V		V																							
MPVMAZDA8	2.3L L3	SYSTEM SEARCH																																	
MPVMAZDA8	2.3L L3	PCM(Powertrain Control Module)								V	V	V	V	V																					
MPVMAZDA8	2.3L L3	ABS(Anti-Lock Brake System)								V	V	V		V																					
MPVMAZDA8	2.3L L3_T	SYSTEM SEARCH																																	
MPVMAZDA8	2.3L L3_T	PCM(Powertrain Control Module)								V		V	V	V																					
MPVMAZDA8	2.3L L3_T	ABS(Anti-Lock Brake System)								V		V											V	V											
MPVMAZDA8	2.3L L3_T	AM(Amplifier Module)								V	V	V																							
MPVMAZDA8	2.3L L3_T	GEM(Generic Electronic Module)								V		V																							
MPVMAZDA8	2.3L L3_T	HCM(Headlamp Control Module)								V		V																							
MPVMAZDA8	2.3L L3_T	ICCM(Intelligent Cruise Control Module)-Beta Test								V		V																							
MPVMAZDA8	2.3L L3_T	IC(Instrument Cluster)								V		V																							
MPVMAZDA8	2.3L L3_T	LTM(Liftgate/Trunk Module)-Beta Test								V		V																							
MPVMAZDA8	2.3L L3_T	RCM(Restraint Control Module)								V		V																							
MPVMAZDA8	2.3L L3_T	RKE(Remote Keyless Entry)								V		V		V																					
MPVMAZDA8	2.3L L3_T	TCM(Transmission Control Module)								V		V																							
MPVMAZDA8	2.3L L3_T	LCM(Lighting Control Module)-Beta Test								V	V																								
MPVMAZDA8	2.3L L3_T	4x4(4x4 Control Module)								V																									
MPVMAZDA8	2.3L L3_T	LPSDM(Left Power Sliding Door Module)								V																									
MPVMAZDA8	2.3L L3_T	RPSDM(Right Power Sliding Door Module)								V																									
ROADSTERMX-5	North America/General specs	2.0L LF	SYSTEM SEARCH																																
ROADSTERMX-5	North America/General specs	2.0L LF	PCM(Powertrain Control Module)	2006~						V	V	V	V	V																					
ROADSTERMX-5	North America/General specs	2.0L LF	PCM(Powertrain Control Module)	2008~						V	V	V	V	V																					
ROADSTERMX-5	North America/General specs	2.0L LF	ABS(Anti-Lock Brake System)							V	V	V		V									V	V											
ROADSTERMX-5	North America/General specs	2.0L LF	IC(Instrument Cluster)							V	V	V																							V
ROADSTERMX-5	North America/General specs	2.0L LF	RCM(Restraint Control Module)							V	V	V																							
ROADSTERMX-5	North America/General specs	2.0L LF	RHT(Retractable Hard Top)							V	V	V																							
ROADSTERMX-5	North America/General specs	2.0L LF	RKE(Remote Keyless Entry)							V	V	V																							
ROADSTERMX-5	North America/General specs	2.0L LF	TCM(Transmission Control Module)							V	V	V	V	V																					
ROADSTERMX-5	North America/General specs	2.0L LF	PATS(Passive anti theft system)-Beta																																
ROADSTERMX-5	North America/General specs	2.0L LF	DHS(Deployable Hood System)							V	V	V																							
ROADSTERMX-5	North America/General specs	1.5L P5	SYSTEM SEARCH																																
ROADSTERMX-5	North America/General specs	1.5L P5	PCM(Powertrain Control Module)					V		V	V	V	V	V																					
ROADSTERMX-5	North America/General specs	1.5L P5	ABS(Anti-Lock Brake System)							V	V	V		V								V	V	V			V								
ROADSTERMX-5	North America/General specs	1.5L P5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)							V	V	V																							
ROADSTERMX-5	North America/General specs	1.5L P5	AM(Amplifier Module)							V	V	V		V																					
ROADSTERMX-5	North America/General specs	1.5L P5	DCDC(DC to DC Converter Control Module)							V	V	V																							
ROADSTERMX-5	North America/General specs	1.5L P5	EATC(Electronic Automatic Temperature Control)							V	V	V																V		V	V				
ROADSTERMX-5	North America/General specs	1.5L P5	EPS(Electronic-Controlled Power Steering)							V	V	V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
ROADSTERMX-5	North America/General specs	1.5L P5	EVP(Electronical VACUUM PUMP)							V	V	V		V																					
ROADSTERMX-5	North America/General specs	1.5L P5	IC(Instrument Cluster)							V		V		V																					
ROADSTERMX-5	North America/General specs	1.5L P5	RCM(Restraint Control Module)							V	V	V																							
ROADSTERMX-5	North America/General specs	1.5L P5	TCM(Transmission Control Module)							V	V	V		V																					
ROADSTERMX-5	North America/General specs	1.5L P5	BSM(Blind Spot Monitoring)							V		V		V																					
ROADSTERMX-5	North America/General specs	1.5L P5	BCM(Body Control Module)							V		V		V																					
ROADSTERMX-5	North America/General specs	1.5L P5	FSC(Forward Sensing Camera)							V	V	V																							
ROADSTERMX-5	North America/General specs	1.5L P5	SSU(Smart Start Unit)							V		V		V																					
ROADSTERMX-5	North America/General specs	1.5L P5	CMU(Connectivity Master Unit)							V	V																								
ROADSTERMX-5	North America/General specs	1.5L P5	ESU(Electric Supply Unit)							V	V																								
ROADSTERMX-5	Europe/General Specs	2.0L LF	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	PCM(Powertrain Control Module)							V	V	V	V	V																					
ROADSTERMX-5	Europe/General Specs	2.0L LF	ABS(Anti-Lock Brake System)							V	V	V		V									V	V											
ROADSTERMX-5	Europe/General Specs	2.0L LF	IC(Instrument Cluster)							V	V	V																							V
ROADSTERMX-5	Europe/General Specs	2.0L LF	RCM(Restraint Control Module)							V	V	V																							
ROADSTERMX-5	Europe/General Specs	2.0L LF	RHT(Retractable Hard Top)							V	V	V																							
ROADSTERMX-5	Europe/General Specs	2.0L LF	RKE(Remote Keyless Entry)							V	V	V																							
ROADSTERMX-5	Europe/General Specs	2.0L LF	TCM(Transmission Control Module)							V	V	V	V	V																					
ROADSTERMX-5	Europe/General Specs	2.0L LF	PATS(Passive anti theft system)-Beta																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	DHS(Deployable Hood System)							V	V	V																							
ROADSTERMX-5	Europe/General Specs	1.8L L8	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	PCM(Powertrain Control Module)							V	V	V	V	V																					
ROADSTERMX-5	Europe/General Specs	1.8L L8	ABS(Anti-Lock Brake System)							V	V	V		V									V	V											
ROADSTERMX-5	Europe/General Specs	1.8L L8	IC(Instrument Cluster)							V	V	V																							V
ROADSTERMX-5	Europe/General Specs	1.8L L8	RCM(Restraint Control Module)							V	V	V																							
ROADSTERMX-5	Europe/General Specs	1.8L L8	RHT(Retractable Hard Top)							V	V	V																							
ROADSTERMX-5	Europe/General Specs	1.8L L8	RKE(Remote Keyless Entry)							V	V	V																							
ROADSTERMX-5	Europe/General Specs	1.8L L8	TCM(Transmission Control Module)							V	V	V	V	V																					
ROADSTERMX-5	Europe/General Specs	1.8L L8	PATS(Passive anti theft system)-Beta																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	PCM(Powertrain Control Module)					V		V	V	V	V	V																					
ROADSTERMX-5	Europe/General Specs	1.5L P5	ABS(Anti-Lock Brake System)							V	V	V		V								V	V	V			V								
ROADSTERMX-5	Europe/General Specs	1.5L P5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)							V	V	V																							
ROADSTERMX-5	Europe/General Specs	1.5L P5	AM(Amplifier Module)							V	V	V		V																					
ROADSTERMX-5	Europe/General Specs	1.5L P5	DCDC(DC to DC Converter Control Module)							V	V	V																							
ROADSTERMX-5	Europe/General Specs	1.5L P5	EATC(Electronic Automatic Temperature Control)							V	V	V																V		V	V				
ROADSTERMX-5	Europe/General Specs	1.5L P5	EPS(Electronic-Controlled Power Steering)							V	V	V																							
ROADSTERMX-5	Europe/General Specs	1.5L P5	EVP(Electronical VACUUM PUMP)							V	V	V		V																					
ROADSTERMX-5	Europe/General Specs	1.5L P5	IC(Instrument Cluster)							V		V		V																					
ROADSTERMX-5	Europe/General Specs	1.5L P5	RCM(Restraint Control Module)							V	V	V																							
ROADSTERMX-5	Europe/General Specs	1.5L P5	TCM(Transmission Control Module)							V	V	V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
ROADSTERMX-5	Europe/General Specs	1.5L P5	BSM(Blind Spot Monitoring)							V		V		V																					
ROADSTERMX-5	Europe/General Specs	1.5L P5	BCM(Body Control Module)							V		V		V																					
ROADSTERMX-5	Europe/General Specs	1.5L P5	FSC(Forward Sensing Camera)							V	V	V																							
ROADSTERMX-5	Europe/General Specs	1.5L P5	SSU(Smart Start Unit)							V		V		V																					
ROADSTERMX-5	Europe/General Specs	1.5L P5	CMU(Connectivity Master Unit)							V	V																								
ROADSTERMX-5	Europe/General Specs	1.5L P5	ESU(Electric Supply Unit)							V	V																								
RX-8	North America Spec	13B	SYSTEM SEARCH																																
RX-8	North America Spec	13B	PCM(Powertrain Control Module)							V	V	V	V	V																					
RX-8	North America Spec	13B	PATS(Passive anti theft system)-Beta																																
RX-8	North America Spec	13B	ABS(Anti-Lock Brake System)							V	V	V		V																					
RX-8	North America Spec	13B	EPS(Electronic-Controlled Power Steering)							V	V	V		V																					
RX-8	North America Spec	13B	IC(Instrument Cluster)							V	V	V																							
RX-8	North America Spec	13B	RCM(Restraint Control Module)							V	V	V																							
RX-8	North America Spec	13B	RKE(Remote Keyless Entry)							V	V	V		V																					
RX-8	North America Spec	13B	TCM(Transmission Control Module)							V	V	V	V	V																					
RX-8	North America Spec	13B	TPM(Tire Pressure Monitor)							V	V	V		V																					
RX-8	North America Spec	13B	LCM(Lighting Control Module)							V	V	V																							
RX-8	North America Spec	13B-MSP High-Power	SYSTEM SEARCH																																
RX-8	North America Spec	13B-MSP High-Power	PCM(Powertrain Control Module)							V	V	V	V	V																					
RX-8	North America Spec	13B-MSP High-Power	PATS(Passive anti theft system)-Beta																																
RX-8	North America Spec	13B-MSP High-Power	ABS(Anti-Lock Brake System)							V	V	V		V																					
RX-8	North America Spec	13B-MSP High-Power	EPS(Electronic-Controlled Power Steering)							V	V	V		V																					
RX-8	North America Spec	13B-MSP High-Power	IC(Instrument Cluster)							V	V	V																							
RX-8	North America Spec	13B-MSP High-Power	RCM(Restraint Control Module)							V	V	V																							
RX-8	North America Spec	13B-MSP High-Power	RKE(Remote Keyless Entry)							V	V	V		V																					
RX-8	North America Spec	13B-MSP High-Power	TCM(Transmission Control Module)							V	V	V	V	V																					
RX-8	North America Spec	13B-MSP High-Power	TPM(Tire Pressure Monitor)							V	V	V		V																					
RX-8	North America Spec	13B-MSP Standard-Power	SYSTEM SEARCH																																
RX-8	North America Spec	13B-MSP Standard-Power	PCM(Powertrain Control Module)							V	V	V	V	V																					
RX-8	North America Spec	13B-MSP Standard-Power	PATS(Passive anti theft system)-Beta																																
RX-8	North America Spec	13B-MSP Standard-Power	ABS(Anti-Lock Brake System)							V	V	V		V																					
RX-8	North America Spec	13B-MSP Standard-Power	EPS(Electronic-Controlled Power Steering)							V	V	V		V																					
RX-8	North America Spec	13B-MSP Standard-Power	IC(Instrument Cluster)							V	V	V																							
RX-8	North America Spec	13B-MSP Standard-Power	RCM(Restraint Control Module)							V	V	V																							
RX-8	North America Spec	13B-MSP Standard-Power	RKE(Remote Keyless Entry)							V	V	V		V																					
RX-8	North America Spec	13B-MSP Standard-Power	TCM(Transmission Control Module)							V	V	V	V	V																					
RX-8	North America Spec	13B-MSP Standard-Power	TPM(Tire Pressure Monitor)							V	V	V		V																					
RX-8	General	13B	SYSTEM SEARCH																																
RX-8	General	13B	PCM(Powertrain Control Module)							V		V	V	V																					
RX-8	General	13B	PATS(Passive anti theft system)-Beta																																
RX-8	General	13B	ABS(Anti-Lock Brake System)							V	V	V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
RX-8	General	13B	EPS(Electronic-Controlled Power Steering)							V	V	V		V																					
RX-8	General	13B	IC(Instrument Cluster)							V	V	V																							
RX-8	General	13B	RCM(Restraint Control Module)							V	V	V																							
RX-8	General	13B	RKE(Remote Keyless Entry)							V		V		V																					
RX-8	General	13B	TCM(Transmission Control Module)							V	V	V	V	V																					
RX-8	General	13B MSP High Power	SYSTEM SEARCH																																
RX-8	General	13B MSP High Power	PCM(Powertrain Control Module)							V		V	V	V																					
RX-8	General	13B MSP High Power	PATS(Passive anti theft system)-Beta																																
RX-8	General	13B MSP High Power	ABS(Anti-Lock Brake System)							V	V	V		V																					
RX-8	General	13B MSP High Power	EPS(Electronic-Controlled Power Steering)							V	V	V		V																					
RX-8	General	13B MSP High Power	IC(Instrument Cluster)							V	V	V																							
RX-8	General	13B MSP High Power	RCM(Restraint Control Module)							V	V	V																							
RX-8	General	13B MSP High Power	RKE(Remote Keyless Entry)							V		V		V																					
RX-8	General	13B MSP High Power	TCM(Transmission Control Module)							V	V	V	V	V																					
RX-8	General	13B MSP Standard Power	SYSTEM SEARCH																																
RX-8	General	13B MSP Standard Power	PCM(Powertrain Control Module)							V		V	V	V																					
RX-8	General	13B MSP Standard Power	PATS(Passive anti theft system)-Beta																																
RX-8	General	13B MSP Standard Power	ABS(Anti-Lock Brake System)							V	V	V		V																					
RX-8	General	13B MSP Standard Power	EPS(Electronic-Controlled Power Steering)							V	V	V		V																					
RX-8	General	13B MSP Standard Power	IC(Instrument Cluster)							V	V	V																							
RX-8	General	13B MSP Standard Power	RCM(Restraint Control Module)							V	V	V																							
RX-8	General	13B MSP Standard Power	RKE(Remote Keyless Entry)							V		V		V																					
RX-8	General	13B MSP Standard Power	TCM(Transmission Control Module)							V	V	V	V	V																					
ESCAPETRIBUTE	Up to 2004	SYSTEM SEARCH																																	
ESCAPETRIBUTE	Up to 2004	PCM(PowerTrain Control Module)								V	V	V		V																					
ESCAPETRIBUTE	Up to 2004	Immobilizer																																	
ESCAPETRIBUTE	Up to 2004	ABS(Anti-Lock Brake System)								V	V	V																							
ESCAPETRIBUTE	Up to 2004	RCM(Restraint Control Module)								V	V	V		V																					
ESCAPETRIBUTE	Up to 2004	GEM(Generic Electronic Module)								V	V	V		V																					
ESCAPETRIBUTE	From 2004	SYSTEM SEARCH																																	
ESCAPETRIBUTE	From 2004	PCM(PowerTrain Control Module)								V	V	V	V	V																					
ESCAPETRIBUTE	From 2004	PATS(Passive anti theft system)																																	
ESCAPETRIBUTE	From 2004	ABS(Anti-Lock Brake System)								V	V	V		V																					
ESCAPETRIBUTE	From 2004	RCM(Restraint Control Module)								V	V	V		V																					
ESCAPETRIBUTE	From 2004	IC(Instrument Cluster)								V	V	V																							
ESCAPETRIBUTE	From 2004	GEM(Generic Electronic Module)								V	V	V		V																					
General(ALL Model)	16PIN CONNECTOR	SYSTEM SEARCH																																	
General(ALL Model)	16PIN CONNECTOR	PCM(PowerTrain Control Module)								V		V	V	V																					
General(ALL Model)	16PIN CONNECTOR	PATS(Passive anti theft system)-Beta																																	
General(ALL Model)	16PIN CONNECTOR	TCM(Transmission Control Module)								V		V	V	V																					
General(ALL Model)	16PIN CONNECTOR	ABS(Anti-Lock Brake System)								V		V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
General(ALL Model)	16PIN CONNECTOR	RCM(Restraint Control Module)								V		V																							
General(ALL Model)	17PIN CONNECTOR	SYSTEM SEARCH																																	
General(ALL Model)	17PIN CONNECTOR	PCM(PowerTrain Control Module)								V		V		V																					
General(ALL Model)	17PIN CONNECTOR	TCM(Transmission Control Module)								V		V		V																					
General(ALL Model)	17PIN CONNECTOR	ABS(Anti-Lock Brake System)								V		V		V																					
General(ALL Model)	17PIN CONNECTOR	RCM(Restraint Control Module)								V		V																							
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	PCM(PowerTrain Control Module)							V																									
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	TCM(Transmission Control Module)							V																									
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	RCM(Restraint Control Module)							V																									
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ABS(Anti-Lock Brake System)							V																									
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ACCM(Air Conditioning Control Module)							V																									
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	4WS(4 Wheel Steering)							V																									
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ICCM(Intelligent Cruise Control Module)							V																									
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	PCM(Powertrain Control Module)							V	V	V	V																						
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	ABS(Anti-Lock Brake System)							V	V	V																							
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	BCM/GEM(Body Control Module/Generic Electronic Module)							V	V	V		V																					
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	EPS(Electronic-Controlled Power Steering)							V	V	V																							
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	IC(Instrument Cluster)							V	V	V																							
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RKE(Remote Keyless Entry)(WithSKE)							V	V	V																							
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RKE(Remote Keyless Entry)(WIthout SKE)							V	V	V																							
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	VSM(Vehicle Security Module)							V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	ASM					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	AT					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	MT					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	PowerShift					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	ABS(Anti-Lock Brake System)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	GEM(Generic Electronic Module)						V	V	V																						V	
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	PCM(Powertrain Control Module)						V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	ABS(Anti-Lock Brake System)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	GEM(Generic Electronic Module)						V	V	V																						V	
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	RKE(Remote Keyless Entry)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 (Low Power without DPF)	ASM					V	V	V	V	V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 (Low Power without DPF)	ALL					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 + DPF (High Power with DPF)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 3(High Power without DPF)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	ABS(Anti-Lock Brake System)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	GEM(Generic Electronic Module)						V	V	V																					V		
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	EPS(Electronic-Controlled Power Steering)						V	V	V																				V			
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 4(Low Power without DPF)						V	V	V	V	V																					
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 4 + DPF (High Power with DPF)						V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 3(High Power without DPF)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	ABS(Anti-Lock Brake System)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	EPS(Electronic-Controlled Power Steering)						V	V	V																				V			
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	RKE(Remote Keyless Entry)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	PCM(Powertrain Control Module)						V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	ABS(Anti-Lock Brake System)						V	V	V										V	V	V											
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	BCM/GEM(Body Control Module/Generic Electronic Module)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	EPS(Electronic-Controlled Power Steering)						V	V	V																				V			
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	FACM(Fuel Additive Control Module)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	IC(Instrument Cluster)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	RKE(Remote Keyless Entry)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.6 Z6	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	PCM(Powertrain Control Module)							V		V	V	V	V	V	V	V		V	V														
BETA-ETC	MAZDA 3 EURO	1.6 Z6	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	1.6 Z6	IC(Instrument Cluster)							V	V	V																							V
BETA-ETC	MAZDA 3 EURO	1.6 Z6	GEM(Generic Electronic Module)							V	V	V																					V		
BETA-ETC	MAZDA 3 EURO	1.6 Z6	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	MAZDA 3 EURO	1.6 Z6	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	ASM					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	AT					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	MT					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	PowerShift					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	EPS(Electronic-Controlled Power Steering)						V	V	V																				V			
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	ABS(Anti-Lock Brake System)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	GEM(Generic Electronic Module)						V	V	V																					V		
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	RCM(Restraint Control Module)						V	V	V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	PCM(Powertrain Control Module)						V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	ABS(Anti-Lock Brake System)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	EPS(Electronic-Controlled Power Steering)						V	V	V																					V		
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	GEM(Generic Electronic Module)						V	V	V																						V	
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	RKE(Remote Keyless Entry)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	PCM(Powertrain Control Module)						V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	ABS(Anti-Lock Brake System)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	FFH(Fuel Fired Coolant Heating Module)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	EPS(Electronic-Controlled Power Steering)						V	V	V																					V		
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	GEM(Generic Electronic Module)						V	V	V																						V	
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	RKE(Remote Keyless Entry)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	ASM					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	AT					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	MT					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	PowerShift					V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	ABS(Anti-Lock Brake System)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	GEM(Generic Electronic Module)						V	V	V																						V	
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	EPS(Electronic-Controlled Power Steering)						V	V	V																					V		
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	PCM(Powertrain Control Module)						V	V	V	V																						
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	ABS(Anti-Lock Brake System)						V	V	V		V																					
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	GEM(Generic Electronic Module)						V	V	V																						V	
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	EPS(Electronic-Controlled Power Steering)						V	V	V																					V		
BETA-ETC	MAZDA GASOLINE ENGINE	PCM(Powertrain Control Module)								V		V	V	V																					
BETA-ETC	MAZDA DIESEL ENGINE	PCM(Powertrain Control Module)								V	V	V	V																						
BETA-ETC	MAZDA 2 ENGINE	PCM(Powertrain Control Module)								V	V	V	V																						
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	PCM(Powertrain Control Module)							V		V	V																						
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	ABS(Anti-Lock Brake System)							V	V	V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	IC(Instrument Cluster)(Include PATS)							V	V	V																							
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	PCM(Powertrain Control Module)							V		V	V																						
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	ABS(Anti-Lock Brake System)							V	V	V																							
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	IC(Instrument Cluster)(Include PATS)							V	V	V																							
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	TCM(Transmission Control Module)							V		V																							
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	PCM(Powertrain Control Module)							V		V	V																						
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	ABS(Anti-Lock Brake System)							V	V	V																							
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	IC(Instrument Cluster)(Include PATS)							V	V	V																							
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	TCM(Transmission Control Module)							V		V																							
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	PCM(Powertrain Control Module)							V		V	V																						
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	ABS(Anti-Lock Brake System)							V	V	V																							
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	IC(Instrument Cluster)(Include PATS)							V	V	V																							
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	SYSTEM SEARCH																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	PCM(Powertrain Control Module)								V		V	V																						
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	ABS(Anti-Lock Brake System)								V	V	V																							
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	EPS(Electronic-Controlled Power Steering)								V	V	V																							
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	IC(Instrument Cluster)								V	V	V																							
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	4x4(4x4 Control Module)								V	V	V																							
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	RCM(Restraint Control Module)								V	V	V																							
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	RKE(Remote Keyless Entry)								V	V	V		V																					
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	SYSTEM SEARCH																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	PCM(Powertrain Control Module)							V	V	V	V																						
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	ABS(Anti-Lock Brake System)							V	V	V																							
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	BCM/GEM(Body Control Module/Generic Electronic Module)							V	V	V		V																					
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	EPS(Electronic-Controlled Power Steering)							V	V	V																							
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	IC(Instrument Cluster)							V	V	V																							
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	RKE(Remote Keyless Entry)							V	V	V																							
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	VSM(Vehicle Security Module)							V	V	V																							
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	TCM(Transmission Control Module)							V	V	V		V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	PCM(Powertrain Control Module)						V		V	V	V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	ABS(Anti-Lock Brake System)						V	V	V										V	V	V			V								
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	EPS(Electronic-Controlled Power Steering)						V	V	V																					V		

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	GEM(Generic Electronic Module)						V	V	V																						V	
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	PCM(Powertrain Control Module)						V		V	V	V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	ABS(Anti-Lock Brake System)						V	V	V										V	V	V			V								
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	EPS(Electronic-Controlled Power Steering)						V	V	V																					V		
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	RKE(Remote Keyless Entry)						V	V	V		V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	PCM(Powertrain Control Module)						V		V	V	V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	ABS(Anti-Lock Brake System)						V	V	V										V	V	V			V								
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	EPS(Electronic-Controlled Power Steering)						V	V	V																					V		
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	PCM(Powertrain Control Module)						V		V	V	V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	ABS(Anti-Lock Brake System)						V	V	V										V	V	V			V								
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	EPS(Electronic-Controlled Power Steering)						V	V	V																					V		
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	RKE(Remote Keyless Entry)						V	V	V		V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	PCM(Powertrain Control Module)						V	V		V																						
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	TCM(Transmission Control Module)						V	V	V		V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	ABS(Anti-Lock Brake System)						V	V	V										V	V	V			V								
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	EPS(Electronic-Controlled Power Steering)						V	V	V																					V		
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	IC(Instrument Cluster)						V	V	V																							
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	BCM/GEM(Body Control Module/Generic Electronic Module)						V	V	V																							
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	MID(Multi-Information Display)						V		V																							
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	PCM(Powertrain Control Module)						V	V	V	V	V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	ABS(Anti-Lock Brake System)						V	V	V										V	V	V			V								
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	EPS(Electronic-Controlled Power Steering)						V	V	V																					V		
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	BCM/GEM(Body Control Module/Generic Electronic Module)						V	V	V																							
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	IC(Instrument Cluster)						V	V	V																							
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	MID(Multi-Information Display)						V		V																							
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	EATC(Electronic Automatic Temperature Control)						V	V	V		V														V	V	V	V				
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	PCM(Powertrain Control Module)						V		V	V	V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	ABS(Anti-Lock Brake System)						V	V	V										V	V	V			V								

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	EPS(Electronic-Controlled Power Steering)						V	V	V																					V		
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	PCM(Powertrain Control Module)						V		V	V	V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	ABS(Anti-Lock Brake System)						V	V	V										V	V	V			V								
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	EPS(Electronic-Controlled Power Steering)						V	V	V																					V		
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	IC(Instrument Cluster)						V	V	V																							V
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	RKE(Remote Keyless Entry)						V	V	V		V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	TCM(Transmission Control Module)						V	V	V																							
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	SYSTEM SEARCH																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	ABS(Anti-Lock Brake System)							V	V	V										V	V	V			V								
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	EPS(Electronic-Controlled Power Steering)							V	V	V																					V		
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	IC(Instrument Cluster)							V	V	V																							V
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	MAZDA 3 (North America/General)	SYSTEM SEARCH																																	
BETA-ETC	MAZDA 3 (North America/General)	PCM(Powertrain Control Module)								V		V	V	V																					
BETA-ETC	MAZDA 3 (North America/General)	ABS(Anti-Lock Brake System)								V	V	V										V	V	V			V								
BETA-ETC	MAZDA 3 (North America/General)	IC(Instrument Cluster)								V	V	V																							V
BETA-ETC	MAZDA 3 (North America/General)	TPM(Tire Pressure Monitor)								V	V	V																							
BETA-ETC	MAZDA 3 (China/General)	1.6L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MAZDA 3 (China/General)	1.6L	ABS(Anti-Lock Brake System)							V	V	V										V	V	V			V								
BETA-ETC	MAZDA 3 (China/General)	1.6L	IC(Instrument Cluster)							V	V	V																							V
BETA-ETC	MAZDA 3 (China/General)	1.6L	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	MAZDA 3 (China/General)	2.0L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MAZDA 3 (China/General)	2.0L	ABS(Anti-Lock Brake System)							V	V	V										V	V	V			V								
BETA-ETC	MAZDA 3 (China/General)	2.0L	EPS(Electronic-Controlled Power Steering)							V	V	V																					V		
BETA-ETC	MAZDA 3 (China/General)	2.0L	IC(Instrument Cluster)							V	V	V																							V
BETA-ETC	MAZDA 3 (China/General)	2.0L	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	SYSTEM SEARCH																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	EPS(Electronic-Controlled Power Steering)							V	V	V																					V		
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	IC(Instrument Cluster)							V	V	V																							V
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	GEM(Generic Electronic Module)							V	V	V																							
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	LPSDM(Left Power Sliding Door Module)							V	V	V																							
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RPSDM(Right Power Sliding Door Module)							V	V	V																							
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	TCM(Transmission Control Module)							V	V	V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	EPS(Electronic-Controlled Power Steering)							V	V	V																				V			
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	IC(Instrument Cluster)							V	V	V																							V
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	GEM(Generic Electronic Module)							V	V	V																							
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	LPSDM(Left Power Sliding Door Module)							V	V	V																							
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RPSDM(Right Power Sliding Door Module)							V	V	V																							
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	TCM(Transmission Control Module)							V	V	V																							
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	EPS(Electronic-Controlled Power Steering)							V	V	V																				V			
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	IC(Instrument Cluster)							V	V	V																							V
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	TCM(Transmission Control Module)							V	V	V																							
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	TPM(Tire Pressure Monitor)							V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	PCM(Powertrain Control Module)						V	V	V	V																						
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	ABS(Anti-Lock Brake System)						V	V	V															V								
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	IC(Instrument Cluster)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	LHID(Left High Intensity Discharge Lamp)						V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	RHID(Right High Intensity Discharge Lamp)						V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	PCM(Powertrain Control Module)						V		V	V																						
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	ABS(Anti-Lock Brake System)						V	V	V															V								
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	GEM(Generic Electronic Module)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	IC(Instrument Cluster)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	LHID(Left High Intensity Discharge Lamp)						V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RHID(Right High Intensity Discharge Lamp)						V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RKE(Remote Keyless Entry)						V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	PCM(Powertrain Control Module)	ALL					V		V	V	V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	PCM(Powertrain Control Module)	MT					V		V	V	V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	ABS(Anti-Lock Brake System)						V	V	V															V								
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	IC(Instrument Cluster)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	LHID(Left High Intensity Discharge Lamp)						V	V	V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	RHID(Right High Intensity Discharge Lamp)						V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	PCM(Powertrain Control Module)	ALL					V		V	V	V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	PCM(Powertrain Control Module)	MT					V		V	V	V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	ABS(Anti-Lock Brake System)						V	V	V														V									
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	GEM(Generic Electronic Module)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	IC(Instrument Cluster)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	LHID(Left High Intensity Discharge Lamp)						V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RHID(Right High Intensity Discharge Lamp)						V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RKE(Remote Keyless Entry)						V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	TCM(Transmission Control Module)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	PCM(Powertrain Control Module)							V	V	V	V																						
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	ABS(Anti-Lock Brake System)							V	V	V														V									
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	GEM(Generic Electronic Module)							V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	IC(Instrument Cluster)							V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	LHID(Left High Intensity Discharge Lamp)							V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RHID(Right High Intensity Discharge Lamp)							V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	TCM(Transmission Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	PCM(Powertrain Control Module)						V	V	V	V																						
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	ABS(Anti-Lock Brake System)						V	V	V														V									
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	GEM(Generic Electronic Module)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	IC(Instrument Cluster)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	LHID(Left High Intensity Discharge Lamp)						V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RHID(Right High Intensity Discharge Lamp)						V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RCM(Restraint Control Module)						V	V	V																							
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RKE(Remote Keyless Entry)						V	V	V		V																					
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	TCM(Transmission Control Module)						V	V	V																							
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	SYSTEM SEARCH																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	ABS(Anti-Lock Brake System)							V	V	V														V									
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	GEM(Generic Electronic Module)							V	V	V																							
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	IC(Instrument Cluster)							V	V	V																							
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	LHID(Left High Intensity Discharge Lamp)							V	V	V		V																					
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RHID(Right High Intensity Discharge Lamp)							V	V	V		V																					
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RCM(Restraint Control Module)							V	V	V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	TCM(Transmission Control Module)							V	V	V																							
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	SYSTEM SEARCH																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	PCM(Powertrain Control Module)	ALL						V		V	V	V																					
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	PCM(Powertrain Control Module)	MT						V	V	V	V																						
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	ABS(Anti-Lock Brake System)							V	V	V															V								
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	GEM(Generic Electronic Module)							V	V	V																							
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	LHID(Left High Intensity Discharge Lamp)							V	V	V		V																					
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RHID(Right High Intensity Discharge Lamp)							V	V	V		V																					
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	IC(Instrument Cluster)							V	V	V																							
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	TCM(Transmission Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	ABS(Anti-Lock Brake System)							V	V	V		V													V								
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	BCM/GEM(Body Control Module/Generic Electronic Module)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	EATC(Electronic Automatic Temperature Control)							V	V	V																V	V	V	V	V			
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	EPS(Electronic-Controlled Power Steering)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	IC(Instrument Cluster)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RVM(Rear Vehicle Monitoring)-Beta Test							V		V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	ABS(Anti-Lock Brake System)							V	V	V		V													V								
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	BCM/GEM(Body Control Module/Generic Electronic Module)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	EATC(Electronic Automatic Temperature Control)							V	V	V																V	V	V	V	V			
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	EPS(Electronic-Controlled Power Steering)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	IC(Instrument Cluster)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	TCM(Transmission Control Module)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RVM(Rear Vehicle Monitoring)-Beta Test							V		V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	PCM(Powertrain Control Module)							V	V	V	V																						
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	ABS(Anti-Lock Brake System)							V	V	V		V													V								
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	BCM/GEM(Body Control Module/Generic Electronic Module)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	EATC(Electronic Automatic Temperature Control)							V	V	V																V	V	V	V	V			
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	EPS(Electronic-Controlled Power Steering)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	IC(Instrument Cluster)							V	V	V		V																					

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	TCM(Transmission Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RVM(Rear Vehicle Monitoring)-Beta Test							V		V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	PCM(Powertrain Control Module)							V	V	V	V																						
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	ABS(Anti-Lock Brake System)							V	V	V															V								
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	BCM/GEM(Body Control Module/Generic Electronic Module)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	EATC(Electronic Automatic Temperature Control)							V	V	V																V	V	V	V	V			
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	FFH(Fuel Fired Coolant Heating Module)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	IC(Instrument Cluster)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	EPS(Electronic-Controlled Power Steering)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	TCM(Transmission Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RVM(Rear Vehicle Monitoring)-Beta Test							V		V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	ABS(Anti-Lock Brake System)							V	V	V		V													V								
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	BCM/GEM(Body Control Module/Generic Electronic Module)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	EATC(Electronic Automatic Temperature Control)							V	V	V																V	V	V	V	V			
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	EPS(Electronic-Controlled Power Steering)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	IC(Instrument Cluster)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RKE(Remote Keyless Entry)							V	V	V		V																					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	TCM(Transmission Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RVM(Rear Vehicle Monitoring)-Beta Test							V		V		V																					
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	PCM(Powertrain Control Module)-ALL							V		V	V	V																					
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	IC(Instrument Cluster)							V	V	V																							
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	TCM(Transmission Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	TPM(Tire Pressure Monitor)							V	V	V																							
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	IC(Instrument Cluster)							V	V	V																							
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	TCM(Transmission Control Module)							V	V	V																							
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	TPM(Tire Pressure Monitor)							V	V	V																							
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	PCM(Powertrain Control Module)							V	V	V																							
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	FFH(Fuel Fired Coolant Heating Module)							V		V																							

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	TCM(Transmission Control Module)							V		V																							
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	RCM(Restraint Control Module)							V	V	V		V																					
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	TCM(Transmission Control Module)							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	GEM(Generic Electronic Module)							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	HCM(Headlamp Control Module)							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	ICCM(Intelligent Cruise Control Module)-Beta Test							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	IC(Instrument Cluster)							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	LTM(Liftgate/Trunk Module)-Beta Test							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	RCM(Restraint Control Module)							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	RKE(Remote Keyless Entry)							V		V		V																					
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	TCM(Transmission Control Module)							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	PCM(Powertrain Control Module)							V		V	V	V																					
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	ABS(Anti-Lock Brake System)							V		V											V	V											
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	GEM(Generic Electronic Module)							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	HCM(Headlamp Control Module)							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	ICCM(Intelligent Cruise Control Module)-Beta Test							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	IC(Instrument Cluster)							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LTM(Liftgate/Trunk Module)-Beta Test							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RCM(Restraint Control Module)							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RKE(Remote Keyless Entry)							V		V		V																					
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	TCM(Transmission Control Module)							V		V																							
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LCM(Lighting Control Module)-Beta Test							V	V																								
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	4x4(4x4 Control Module)							V																									
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LPSDM(Left Power Sliding Door Module)							V																									
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RPSDM(Right Power Sliding Door Module)							V																									

Vehicle	Capacity	System 1	System 2	System 3	System 4	Incode calculator	Reset The Oil Change Indicator	Oil Light Reset / Service Light Reset	Throttle Body Learning	DTC Analysis	DTC EraseMemory	Data Analysis	ECU Information Display	Actuation Test	Reset the frequency of the starter relay activations	Reset the frequency of the starter motor activations	Reset the frequency of the fuel pump relay activations	Reset the frequency of the fuel pump activations	Reset tge frequency of the power relay activations	Reset the frequency of the power drive relay activations	Reset the cumulative number of sub-battery operations	Brake Fluid pressure sensor	Lateral Acceleration Sensor	Yaw rate sensor	Brake Fluid Pressure Sensor Inintialize	Lateral Acceleration Sensor Inintialize	Longitudinal Acceleration Sensor	Air Mix Actuator	Air Intake Actuator/Air conditioning compressor	Illumination Of All Indicator Lights	Blower Motor Speed	Airflow Mode Actuator	EPS Module Installation	GEM Reset	IC Module Istallation
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	SYSTEM SEARCH																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	PCM(Powertrain Control Module)							V	V	V	V																						
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	IC(Instrument Cluster)							V	V	V																							
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	TCM(Transmission Control Module)							V	V	V		V																					
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	SYSTEM SEARCH																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	2005~						V	V	V	V																						
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	~2005						V	V	V	V																						
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	TCM(Transmission Control Module)							V	V	V		V																					
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	SYSTEM SEARCH																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	PCM(Powertrain Control Module)							V	V	V	V																						
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	RCM(Restraint Control Module)							V	V	V																							
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	TCM(Transmission Control Module)							V	V	V		V																					
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	SYSTEM SEARCH																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	PCM(Powertrain Control Module)							V	V	V	V																						
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	ABS(Anti-Lock Brake System)							V	V	V		V																					
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	TCM(Transmission Control Module)							V	V	V		V																					
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	PCM(Powertrain Control Module)							V	V	V	V																						
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	ABS(Anti-Lock Brake System)							V	V	V																							
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	GEM(Generic Electronic Module)							V	V	V		V																					
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	IC(Instrument Cluster)							V	V	V																							
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	RCM(Restraint Control Module)							V	V	V		V																					
BETA-ETC	TITAN DASH	2.0L RF_T	SYSTEM SEARCH																																
BETA-ETC	TITAN DASH	2.0L RF_T	PCM(Powertrain Control Module)							V	V	V	V																						
BETA-ETC	TITAN DASH	2.0L RF_T	TCM(Transmission Control Module)							V	V	V		V																					
BETA-ETC	PATS(Passive anti theft system)																																		
BETA-ETC	Vehicle Log Capture																																		

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
Incode Calculator	Incode Calculator	~2010.05																																	
Service Manual	Reset the Oil Change Indicator(G-scan Support)																																		
Service Manual	Oil Light Reset / Service Light Reset(Manual)																																		
Service Manual	Throttle Body Learning																																		
BIANTE	2.0L LF	SYSTEM SEARCH																																	
BIANTE	2.0L LF	PCM(Powertrain Control Module)																																	
BIANTE	2.0L LF	ABS(Anti-Lock Brake System)																																	
BIANTE	2.0L LF	EATC(Electronic Automatic Temperature Control)																																	
BIANTE	2.0L LF	EPS(Electronic-Controlled Power Steering)																																	
BIANTE	2.0L LF	GEM(Generic Electronic Module)																																	
BIANTE	2.0L LF	IC(Instrument Cluster)																																	
BIANTE	2.0L LF	LPSDM(Left Power Sliding Door Module)				V	V																												
BIANTE	2.0L LF	RCM(Restraint Control Module)						V																											
BIANTE	2.0L LF	RKE(Remote Keyless Entry)																																	
BIANTE	2.0L LF	RPSDM(Right Power Sliding Door Module)				V	V																												
BIANTE	2.0L LF	TCM(Transmission Control Module)																																	
BIANTE	2.3L L3	SYSTEM SEARCH																																	
BIANTE	2.3L L3	PCM(Powertrain Control Module)																																	
BIANTE	2.3L L3	ABS(Anti-Lock Brake System)																																	
BIANTE	2.3L L3	EATC(Electronic Automatic Temperature Control)																																	
BIANTE	2.3L L3	EPS(Electronic-Controlled Power Steering)																																	
BIANTE	2.3L L3	GEM(Generic Electronic Module)																																	
BIANTE	2.3L L3	IC(Instrument Cluster)																																	
BIANTE	2.3L L3	LPSDM(Left Power Sliding Door Module)				V	V																												
BIANTE	2.3L L3	RCM(Restraint Control Module)						V																											
BIANTE	2.3L L3	RKE(Remote Keyless Entry)																																	
BIANTE	2.3L L3	RPSDM(Right Power Sliding Door Module)				V	V																												
BIANTE	2.3L L3	TCM(Transmission Control Module)																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	SYSTEM SEARCH																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	2005~						V	V	V	V	V	V	V	V	V	V	V	V	V	V	V												
BONGOBRAWNYSPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	~2005																					V	V										
BONGOBRAWNYSPECTRON	2.0L RF_T	ABS(Anti-Lock Brake System)																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.2 Diesel	SYSTEM SEARCH																																	
BT-50(RANGER)	2.2 Diesel	PCM(PowerTrain Control Module)																						V		V	V	V	V	V	V	V	V	V	V
BT-50(RANGER)	2.2 Diesel	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	2.2 Diesel	ACM(Audio Control Module)																																	
BT-50(RANGER)	2.2 Diesel	BCMii(Body Control Module)																																	
BT-50(RANGER)	2.2 Diesel	DDM(Drivers Door Module)																																	
BT-50(RANGER)	2.2 Diesel	FCDIM(Front Control/Display Interface Module)																																	
BT-50(RANGER)	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BT-50(RANGER)	2.2 Diesel	IPC(Instrument Panel Control Module)																																	
BT-50(RANGER)	2.2 Diesel	PAM(Parking Aid Module)																																	
BT-50(RANGER)	2.2 Diesel	PDM(Passengers Door Module)																																	
BT-50(RANGER)	2.2 Diesel	RCM(Restraint Control Module)						V																											
BT-50(RANGER)	2.2 Diesel	SRM(Speech Recognition Module)																																	
BT-50(RANGER)	2.2 Diesel	TBM(Tracking And Blocking Module)																																	
BT-50(RANGER)	2.2 Diesel	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.2 Diesel	TRM(Trailer Module)																																	
BT-50(RANGER)	2.2 Diesel	PATS(Passive anti theft system)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)														V								V											
BT-50(RANGER)	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)														V								V											
BT-50(RANGER)	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)																																	
BT-50(RANGER)	3.2 Diesel	SYSTEM SEARCH																																	
BT-50(RANGER)	3.2 Diesel	PCM(PowerTrain Control Module)																						V		V	V	V	V	V	V	V	V	V	V
BT-50(RANGER)	3.2 Diesel	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	3.2 Diesel	ACM(Audio Control Module)																																	
BT-50(RANGER)	3.2 Diesel	BCMii(Body Control Module)																																	
BT-50(RANGER)	3.2 Diesel	DDM(Drivers Door Module)																																	
BT-50(RANGER)	3.2 Diesel	FCDIM(Front Control/Display Interface Module)																																	
BT-50(RANGER)	3.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																	
BT-50(RANGER)	3.2 Diesel	IPC(Instrument Panel Control Module)																																	
BT-50(RANGER)	3.2 Diesel	PAM(Parking Aid Module)																																	
BT-50(RANGER)	3.2 Diesel	PDM(Passengers Door Module)																																	
BT-50(RANGER)	3.2 Diesel	RCM(Restraint Control Module)						V																											
BT-50(RANGER)	3.2 Diesel	SRM(Speech Recognition Module)																																	
BT-50(RANGER)	3.2 Diesel	TBM(Tracking And Blocking Module)																																	
BT-50(RANGER)	3.2 Diesel	TCM(Transmission Control Module)																																	
BT-50(RANGER)	3.2 Diesel	TRM(Trailer Module)																																	
BT-50(RANGER)	3.2 Diesel	PATS(Passive anti theft system)																																	
BT-50(RANGER)	2.3 Gasoline	PCM(Powertrain Control Module)																								V									
BT-50(RANGER)	2.3 Gasoline	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	2.3 Gasoline	GEM(Generic Electronic Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BT-50(RANGER)	2.3 Gasoline	IC(Instrument Cluster)																																	
BT-50(RANGER)	2.3 Gasoline	OCSM(Occupant Classification System Module)																																	
BT-50(RANGER)	2.3 Gasoline	4x4(4x4 Control Module)																																	
BT-50(RANGER)	2.3 Gasoline	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.3 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																	
BT-50(RANGER)	2.3 Gasoline	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	2.5 Gasoline	PCM(PowerTrain Control Module)																														V			
BT-50(RANGER)	2.5 Gasoline	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	2.5 Gasoline	ACM(Audio Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	BCMii(Body Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	DDM(Drivers Door Module)																																	
BT-50(RANGER)	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																																	
BT-50(RANGER)	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																																	
BT-50(RANGER)	2.5 Gasoline	IPC(Instrument Panel Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	PAM(Parking Aid Module)																																	
BT-50(RANGER)	2.5 Gasoline	PDM(Passengers Door Module)																																	
BT-50(RANGER)	2.5 Gasoline	RCM(Restraint Control Module)						V																											
BT-50(RANGER)	2.5 Gasoline	SRM(Speech Recognition Module)																																	
BT-50(RANGER)	2.5 Gasoline	TBM(Tracking And Blocking Module)																																	
BT-50(RANGER)	2.5 Gasoline	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	TRM(Trailer Module)																																	
BT-50(RANGER)	2.5 Gasoline	PATS(Passive anti theft system)																																	
BT-50(RANGER)	3.0 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	3.0 Gasoline	PCM(Powertrain Control Module)																								V									
BT-50(RANGER)	3.0 Gasoline	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	3.0 Gasoline	GEM(Generic Electronic Module)																																	
BT-50(RANGER)	3.0 Gasoline	IC(Instrument Cluster)																																	
BT-50(RANGER)	3.0 Gasoline	OCSM(Occupant Classification System Module)																																	
BT-50(RANGER)	3.0 Gasoline	4x4(4x4 Control Module)																																	
BT-50(RANGER)	3.0 Gasoline	RCM(Restraint Control Module)																																	
BT-50(RANGER)	3.0 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																	
BT-50(RANGER)	3.0 Gasoline	TCM(Transmission Control Module)																																	
BT-50(RANGER)	4.0 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	4.0 Gasoline	PCM(Powertrain Control Module)																								V									
BT-50(RANGER)	4.0 Gasoline	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	4.0 Gasoline	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																	
BT-50(RANGER)	4.0 Gasoline	IC(Instrument Cluster)																																	
BT-50(RANGER)	4.0 Gasoline	OCSM(Occupant Classification System Module)																																	
BT-50(RANGER)	4.0 Gasoline	4x4(4x4 Control Module)																																	
BT-50(RANGER)	4.0 Gasoline	RCM(Restraint Control Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BT-50(RANGER)	4.0 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																	
BT-50(RANGER)	4.0 Gasoline	TCM(Transmission Control Module)																																	
CX-3	1.5L S5	SYSTEM SEARCH																																	
CX-3	1.5L S5	PCM(Powertrain Control Module)							V		V		V	V	V																				
CX-3	1.5L S5	TCM(Transmission Control Module)																																	
CX-3	1.5L S5	4x4(4x4 Control Module)																																	
CX-3	1.5L S5	ABS(Anti-Lock Brake System)																																	
CX-3	1.5L S5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																	
CX-3	1.5L S5	EATC(Electronic Automatic Temperature Control)																																	
CX-3	1.5L S5	EPS(Electronic-Controlled Power Steering)																																	
CX-3	1.5L S5	ESU(Electric Supply Unit)																																	
CX-3	1.5L S5	IC(Instrument Cluster)																																	
CX-3	1.5L S5	RCM(Restraint Control Module)						V																											
CX-3	1.5L S5	BSM(Blind Spot Monitoring)																																	
CX-3	1.5L S5	BCM(Body Control Module)																																	
CX-3	1.5L S5	CMU(Connectivity Master Unit)																																	
CX-3	1.5L S5	FSC(Forward Sensing Camera)																																	
CX-3	1.5L S5	SSU(Smart Start Unit)																																	
CX-3	1.5L S5	SCBS(Smart City Brake Support)																																	
CX-3	1.5L S5	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-3	2.0L PE	SYSTEM SEARCH																																	
CX-3	2.0L PE	PCM(Powertrain Control Module)																																	
CX-3	2.0L PE	TCM(Transmission Control Module)																																	
CX-3	2.0L PE	4x4(4x4 Control Module)																																	
CX-3	2.0L PE	ABS(Anti-Lock Brake System)																																	
CX-3	2.0L PE	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																	
CX-3	2.0L PE	EATC(Electronic Automatic Temperature Control)																																	
CX-3	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
CX-3	2.0L PE	ESU(Electric Supply Unit)																																	
CX-3	2.0L PE	IC(Instrument Cluster)																																	
CX-3	2.0L PE	RCM(Restraint Control Module)						V																											
CX-3	2.0L PE	BSM(Blind Spot Monitoring)																																	
CX-3	2.0L PE	BCM(Body Control Module)																																	
CX-3	2.0L PE	CMU(Connectivity Master Unit)																																	
CX-3	2.0L PE	FSC(Forward Sensing Camera)																																	
CX-3	2.0L PE	SSU(Smart Start Unit)																																	
CX-3	2.0L PE	SCBS(Smart City Brake Support)																																	
CX-3	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.0L PE	SYSTEM SEARCH																																	
CX-5	2.0L PE	PCM(Powertrain Control Module)																																	
CX-5	2.0L PE	TCM(Transmission Control Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
CX-5	2.0L PE	4x4(4x4 Control Module)																																	
CX-5	2.0L PE	ABS(Anti-Lock Brake System)																																	
CX-5	2.0L PE	ACU(Audio Control Unit)																																	
CX-5	2.0L PE	EATC(Electronic Automatic Temperature Control)																																	
CX-5	2.0L PE	AM(Amplifier Module)																																	
CX-5	2.0L PE	AFS(Adaptive Front Lighting System)																																	
CX-5	2.0L PE	DSM(Drivers Seat Module)																																	
CX-5	2.0L PE	DCDC(DC to DC Converter Control Module)																																	
CX-5	2.0L PE	FSC(Forward Sensing Camera)																																	
CX-5	2.0L PE	SCBS(Smart City Brake Support)																																	
CX-5	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
CX-5	2.0L PE	IC(Instrument Cluster)																																	
CX-5	2.0L PE	RVM(Rear Vehicle Monitoring)																																	
CX-5	2.0L PE	RCM(Restraint Control Module)						V																											
CX-5	2.0L PE	SSU(Smart Start Unit)																																	
CX-5	2.0L PE	BSM(Blind Spot Monitoring)																																	
CX-5	2.0L PE	F_BCM(Front Body Control Module)																																	
CX-5	2.0L PE	R_BCM(Rear Body Control Module)																																	
CX-5	2.2L SH	SYSTEM SEARCH																																	
CX-5	2.2L SH	PCM(Powertrain Control Module)							V		V		V	V	V																				
CX-5	2.2L SH	TCM(Transmission Control Module)																																	
CX-5	2.2L SH	4x4(4x4 Control Module)																																	
CX-5	2.2L SH	ABS(Anti-Lock Brake System)																																	
CX-5	2.2L SH	ACU(Audio Control Unit)																																	
CX-5	2.2L SH	CMU(Connectivity Master Unit)																																	
CX-5	2.2L SH	EATC(Electronic Automatic Temperature Control)																																	
CX-5	2.2L SH	AM(Amplifier Module)																																	
CX-5	2.2L SH	AFS(Adaptive Front Lighting System)																																	
CX-5	2.2L SH	DSM(Drivers Seat Module)																																	
CX-5	2.2L SH	DCDC(DC to DC Converter Control Module)																																	
CX-5	2.2L SH	FSC(Forward Sensing Camera)																																	
CX-5	2.2L SH	SCBS(Smart City Brake Support)																																	
CX-5	2.2L SH	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.2L SH	EPB(Electonic Parking Brake)																																	
CX-5	2.2L SH	EPS(Electronic-Controlled Power Steering)																																	
CX-5	2.2L SH	IC(Instrument Cluster)																																	
CX-5	2.2L SH	RVM(Rear Vehicle Monitoring)																																	
CX-5	2.2L SH	RCM(Restraint Control Module)						V																											
CX-5	2.2L SH	SSU(Smart Start Unit)																																	
CX-5	2.2L SH	BSM(Blind Spot Monitoring)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
CX-5	2.2L SH	F_BCM(Front Body Control Module)																																	
CX-5	2.2L SH	R_BCM(Rear Body Control Module)																																	
CX-5	2.5L PY	SYSTEM SEARCH																																	
CX-5	2.5L PY	PCM(Powertrain Control Module)																																	
CX-5	2.5L PY	TCM(Transmission Control Module)																																	
CX-5	2.5L PY	4x4(4x4 Control Module)																																	
CX-5	2.5L PY	ABS(Anti-Lock Brake System)																																	
CX-5	2.5L PY	AM(Amplifier Module)																																	
CX-5	2.5L PY	DSM(Drivers Seat Module)																																	
CX-5	2.5L PY	EATC(Electronic Automatic Temperature Control)																																	
CX-5	2.5L PY	EPB(Electonic Parking Brake)																																	
CX-5	2.5L PY	EPS(Electronic-Controlled Power Steering)																																	
CX-5	2.5L PY	IC(Instrument Cluster)																																	
CX-5	2.5L PY	RCM(Restraint Control Module)						V																											
CX-5	2.5L PY	AFS(Adaptive Front Lighting System)																																	
CX-5	2.5L PY	FSC(Forward Sensing Camera)																																	
CX-5	2.5L PY	SSU(Smart Start Unit)																																	
CX-5	2.5L PY	BSM(Blind Spot Monitoring)-JAPAN																																	
CX-5	2.5L PY	BSML(Blind Spot Monitoring Left)																																	
CX-5	2.5L PY	BSMR(Blind Spot Monitoring Right)																																	
CX-5	2.5L PY	F_BCM(Front Body Control Module)																																	
CX-5	2.5L PY	R_BCM(Rear Body Control Module)																																	
CX-5	2.5L PY	SCBS(Smart City Brake Support)																																	
CX-5	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.5L PY	ACU(Audio Control Unit)																																	
CX-5	2.5L PY	CMU(Connectivity Master Unit)																																	
CX-7	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
CX-7	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)							V	V	V	V	V	V	V	V		V			V	V													
CX-7	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
CX-7	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																	
CX-7	2.2L R2_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
CX-7	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
CX-7	2.2L R2_T (Diesel)	GEM(Generic Electronic Module)																																	
CX-7	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																	
CX-7	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																																	
CX-7	2.2L R2_T (Diesel)	MID(Multi-Information Display)																																	
CX-7	2.2L R2_T (Diesel)	SCR CU(Selective Catalytic Reduction)																																	
CX-7	2.2L R2_T (Diesel)	RKE(Remote Keyless Entry)																																	
CX-7	2.2L R2_T (Diesel)	RVM(Rear Vehicle Monitoring)																																	
CX-7	2.2L R2_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																	
CX-7	2.3L L3_T	SYSTEM SEARCH																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
CX-7	2.3L L3_T	PCM(Powertrain Control Module)																																	
CX-7	2.3L L3_T	PATS(Passive anti theft system)-Beta																																	
CX-7	2.3L L3_T	ABS(Anti-Lock Brake System)																																	
CX-7	2.3L L3_T	EATC(Electronic Automatic Temperature Control)																																	
CX-7	2.3L L3_T	AM(Amplifier Module)																																	
CX-7	2.3L L3_T	GEM(Generic Electronic Module)																																	
CX-7	2.3L L3_T	IC(Instrument Cluster)																																	
CX-7	2.3L L3_T	RCM(Restraint Control Module)																																	
CX-7	2.3L L3_T	TCM(Transmission Control Module)																																	
CX-7	2.3L L3_T	ACU(Audio Control Unit)																																	
CX-7	2.3L L3_T	4*4(4*4 Control Module)																																	
CX-7	2.3L L3_T	MID(Multi-Information Display)																																	
CX-7	2.3L L3_T	RKE(Remote Keyless Entry)																																	
CX-7	2.3L L3_T	LCM(Lighting Control Module)																																	
CX-7	2.3L L3_T	RVM(Rear Vehicle Monitoring)																																	
CX-7	2.5L L5	SYSTEM SEARCH																																	
CX-7	2.5L L5	PCM(Powertrain Control Module)																																	
CX-7	2.5L L5	PATS(Passive anti theft system)-Beta																																	
CX-7	2.5L L5	TCM(Transmission Control Module)																																	
CX-7	2.5L L5	ABS(Anti-Lock Brake System)																																	
CX-7	2.5L L5	RCM(Restraint Control Module)																																	
CX-7	2.5L L5	GEM(Generic Electronic Module)																																	
CX-7	2.5L L5	IC(Instrument Cluster)																																	
CX-7	2.5L L5	MID(Multi-Information Display)-Beta Test																																	
CX-7	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	
CX-7	2.5L L5	ACU(Audio Control Unit)																																	
CX-7	2.5L L5	ICCM(Intelligent Cruise Control Module)																																	
CX-7	2.5L L5	RKE(Remote Keyless Entry)																																	
CX-7	2.5L L5	RVM(Rear Vehicle Monitoring)																																	
CX-7	2.5L L5	LCM(Lighting Control Module)																																	
CX-9	3.7L CA	SYSTEM SEARCH																																	
CX-9	3.7L CA	PCM(Powertrain Control Module)																																	
CX-9	3.7L CA	PATS(Passive anti theft system)-Beta																																	
CX-9	3.7L CA	ABS(Anti-Lock Brake System)																																	
CX-9	3.7L CA	4WD(Four Wheel Drive)-Beta Test																																	
CX-9	3.7L CA	DSM(Drivers Seat Module)																																	
CX-9	3.7L CA	GEM(Generic Electronic Module)																																	
CX-9	3.7L CA	IC(Instrument Cluster) - Without Tire Pressure Monitor																																	
CX-9	3.7L CA	IC(Instrument Cluster) - With Tire Pressure Monitor-Beta Test				V																													
CX-9	3.7L CA	LCM(Lighting Control Module)-Beta Test																																	
CX-9	3.7L CA	LTM(Liftgate/Trunk Module)-Beta Test																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
CX-9	3.7L CA	RCM(Restraint Control Module) - Except USA																																	
CX-9	3.7L CA	RCM(Restraint Control Module) - USA-Beta Test																																	
CX-9	3.7L CA	RKE(Remote Keyless Entry)-Beta Test																																	
CX-9	3.7L CA	TCM(Transmission Control Module)																																	
CX-9	3.7L CA	BSML(Blind Spot Monitoring Left)-Beta Test																																	
CX-9	3.7L CA	BSMR(Blind Spot Monitoring Right)-Beta Test																																	
CX-9	3.5L CY-Beta Test	SYSTEM SEARCH																																	
CX-9	3.5L CY-Beta Test	PCM(Powertrain Control Module)																																	
CX-9	3.5L CY-Beta Test	PATS(Passive anti theft system)-Beta																																	
CX-9	3.5L CY-Beta Test	ABS(Anti-Lock Brake System)																																	
CX-9	3.5L CY-Beta Test	4WD(Four Wheel Drive)																																	
CX-9	3.5L CY-Beta Test	GEM(Generic Electronic Module)																																	
CX-9	3.5L CY-Beta Test	IC(Instrument Cluster) - Without Tire Pressure Monitor																																	
CX-9	3.5L CY-Beta Test	IC(Instrument Cluster) - With Tire Pressure Monitor				V																													
CX-9	3.5L CY-Beta Test	LTM(Liftgate/Trunk Module)																																	
CX-9	3.5L CY-Beta Test	RCM(Restraint Control Module) - USA																																	
CX-9	3.5L CY-Beta Test	RKE(Remote Keyless Entry)																																	
CX-9	3.5L CY-Beta Test	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.3L ZJ	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	PATS(Passive anti theft system)-Beta																																	
DEMIOVERISAMAZDA2	1.3L ZJ	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	RKE(Remote Keyless Entry)																																	
DEMIOVERISAMAZDA2	1.3L P3	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.3L P3	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.3L P3	BCM(Body Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	EATC(Electronic Automatic Temperature Control)																																	
DEMIOVERISAMAZDA2	1.3L P3	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.3L P3	FSC(Forward Sensing Camera)																																	
DEMIOVERISAMAZDA2	1.3L P3	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.3L P3	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	SSU(Smart Start Unit)																																	
DEMIOVERISAMAZDA2	1.3L P3	SCBS(Smart City Brake Support)																																	
DEMIOVERISAMAZDA2	1.3L P3	ALM(Auto Leveling Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	BSM(Blind Spot Monitoring)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
DEMIOVERISAMAZDA2	1.3L P3	CMU(Connectivity Master Unit)																																	
DEMIOVERISAMAZDA2	1.3L P3	ESU(Electric Supply Unit)																																	
DEMIOVERISAMAZDA2	1.5L ZY	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L ZY	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.5L ZY	PATS(Passive anti theft system)-Beta																																	
DEMIOVERISAMAZDA2	1.5L ZY	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.5L ZY	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.5L ZY	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.5L ZY	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
DEMIOVERISAMAZDA2	1.5L ZY	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.5L ZY	RKE(Remote Keyless Entry)	With SKE																																
DEMIOVERISAMAZDA2	1.5L ZY	RKE(Remote Keyless Entry)	Without SKE																																
DEMIOVERISAMAZDA2	1.5L ZY	VSM(Vehicle Security Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L P5	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.5L P5	EATC(Electronic Automatic Temperature Control)																																	
DEMIOVERISAMAZDA2	1.5L P5	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.5L P5	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.5L P5	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	BSM(Blind Spot Monitoring)																																	
DEMIOVERISAMAZDA2	1.5L P5	BCM(Body Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	FSC(Forward Sensing Camera)																																	
DEMIOVERISAMAZDA2	1.5L P5	SSU(Smart Start Unit)																																	
DEMIOVERISAMAZDA2	1.5L P5	SCBS(Smart City Brake Support)																																	
DEMIOVERISAMAZDA2	1.5L P5	ALM(Auto Leveling Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	CMU(Connectivity Master Unit)																																	
DEMIOVERISAMAZDA2	1.5L P5	ESU(Electric Supply Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L S5	PCM(Powertrain Control Module)							V		V		V	V	V																				
DEMIOVERISAMAZDA2	1.5L S5	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	4x4(4x4 Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.5L S5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	EATC(Electronic Automatic Temperature Control)																																	
DEMIOVERISAMAZDA2	1.5L S5	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.5L S5	ESU(Electric Supply Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.5L S5	RCM(Restraint Control Module)						V																											
DEMIOVERISAMAZDA2	1.5L S5	BSM(Blind Spot Monitoring)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
DEMIOVERISAMAZDA2	1.5L S5	BCM(Body Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	CMU(Connectivity Master Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	FSC(Forward Sensing Camera)																																	
DEMIOVERISAMAZDA2	1.5L S5	SSU(Smart Start Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	SCBS(Smart City Brake Support)																																	
DEMIOVERISAMAZDA2	1.5L S5	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	PCM(Powertrain Control Module)																						V		V									
DEMIOVERISAMAZDA2	1.6L Y6-Beta	PATS(Passive anti theft system)-Beta																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RKE(Remote Keyless Entry)	With SKE																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RKE(Remote Keyless Entry)	Without SKE																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	VSM(Vehicle Security Module)																																	
AXELAMAZDA3	1.5L ZY	SYSTEM SEARCH																																	
AXELAMAZDA3	1.5L ZY	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	1.5L ZY	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	1.5L ZY	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	1.5L ZY	RCM(Restraint Control Module)						V																											
AXELAMAZDA3	1.5L ZY	IC(Instrument Cluster)																																	
AXELAMAZDA3	1.5L ZY	GEM(Generic Electronic Module)																																	
AXELAMAZDA3	1.5L ZY	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	1.6L Y6	SYSTEM SEARCH																																	
AXELAMAZDA3	1.6L Y6	PCM(Powertrain Control Module)																						V		V		V	V	V		V	V	V	V
AXELAMAZDA3	1.6L Y6	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	1.6L Y6	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	1.6L Y6	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	1.6L Y6	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	1.6L Y6	FACM(Fuel Additive Control Module)																																	
AXELAMAZDA3	1.6L Y6	IC(Instrument Cluster)																																	
AXELAMAZDA3	1.6L Y6	RCM(Restraint Control Module)						V																											
AXELAMAZDA3	1.6L Y6	RKE(Remote Keyless Entry)																																	
AXELAMAZDA3	1.6L Y6	BSML(Blind Spot Monitoring Left)																																	
AXELAMAZDA3	1.6L Y6	BSMR(Blind Spot Monitoring Right)																																	
AXELAMAZDA3	1.6L Y6	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	1.6L Y6	MID(Multi-Information Display)																																	
AXELAMAZDA3	1.6L Y6	ACU(Audio Control Unit)																																	
AXELAMAZDA3	1.6L Y6	PATS(Passive anti theft system)-Beta																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
AXELAMAZDA3	1.6L Z6	SYSTEM SEARCH																																	
AXELAMAZDA3	1.6L Z6	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	1.6L Z6	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	1.6L Z6	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	1.6L Z6	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	1.6L Z6	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	1.6L Z6	IC(Instrument Cluster)																																	
AXELAMAZDA3	1.6L Z6	GEM(Generic Electronic Module)																																	
AXELAMAZDA3	1.6L Z6	MID(Multi-Information Display)																																	
AXELAMAZDA3	1.6L Z6	RCM(Restraint Control Module)						V																											
AXELAMAZDA3	1.6L Z6	ACU(Audio Control Unit)																																	
AXELAMAZDA3	1.6L Z6	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.0L LF	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L LF	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.0L LF	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.0L LF	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.0L LF	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.0L LF	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.0L LF	RCM(Restraint Control Module)						V																											
AXELAMAZDA3	2.0L LF	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.0L LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.0L LF	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.0L LF	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.0L LF	GEM(Generic Electronic Module)																																	
AXELAMAZDA3	2.0L LF	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.0L PE	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L PE	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.0L PE	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.0L PE	4x4(4x4 Control Module)																																	
AXELAMAZDA3	2.0L PE	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.0L PE	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.0L PE	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.0L PE	AM(Amplifier Module)																																	
AXELAMAZDA3	2.0L PE	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.0L PE	DSM(Drivers Seat Module)																																	
AXELAMAZDA3	2.0L PE	DCDC(DC to DC Converter Control Module)																																	
AXELAMAZDA3	2.0L PE	FSC(Forward Sensing Camera)																																	
AXELAMAZDA3	2.0L PE	SCBS(Smart City Brake Support)																																	
AXELAMAZDA3	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
AXELAMAZDA3	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.0L PE	IC(Instrument Cluster)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
AXELAMAZDA3	2.0L PE	RVM(Rear Vehicle Monitoring)																																	
AXELAMAZDA3	2.0L PE	RCM(Restraint Control Module)						V																											
AXELAMAZDA3	2.0L PE	SSU(Smart Start Unit)																																	
AXELAMAZDA3	2.0L PE	F_BCM(Front Body Control Module)																																	
AXELAMAZDA3	2.0L PE	R_BCM(Rear Body Control Module)																																	
AXELAMAZDA3	2.0L PE	CMU(Connectivity Master Unit)																																	
AXELAMAZDA3	2.3L L3_T	SYSTEM SEARCH																																	
AXELAMAZDA3	2.3L L3_T	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.3L L3_T	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.3L L3_T	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.3L L3_T	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.3L L3_T	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.3L L3_T	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.3L L3_T	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.3L L3_T	RCM(Restraint Control Module)						V																											
AXELAMAZDA3	2.3L L3_T	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.3L L3_T	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.3L L3_T	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.3L L3_T	LCM(Lighting Control Module)																																	
AXELAMAZDA3	2.3L L3_T	RKE(Remote Keyless Entry)																																	
AXELAMAZDA3	2.3L L3_T	TPM(Tire Pressure Monitor)				V																													
AXELAMAZDA3	2.3L L3_T	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.5L L5	SYSTEM SEARCH																																	
AXELAMAZDA3	2.5L L5	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.5L L5	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.5L L5	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.5L L5	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.5L L5	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.5L L5	RCM(Restraint Control Module)						V																											
AXELAMAZDA3	2.5L L5	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.5L L5	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.5L L5	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.5L L5	RKE(Remote Keyless Entry)																																	
AXELAMAZDA3	2.5L PY	SYSTEM SEARCH																																	
AXELAMAZDA3	2.5L PY	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.5L PY	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.5L PY	4x4(4x4 Control Module)																																	
AXELAMAZDA3	2.5L PY	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.5L PY	AM(Amplifier Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
AXELAMAZDA3	2.5L PY	DSM(Drivers Seat Module)																																	
AXELAMAZDA3	2.5L PY	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.5L PY	EPB(Electonic Parking Brake)																																	
AXELAMAZDA3	2.5L PY	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.5L PY	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.5L PY	RCM(Restraint Control Module)						V																											
AXELAMAZDA3	2.5L PY	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.5L PY	FSC(Forward Sensing Camera)																																	
AXELAMAZDA3	2.5L PY	SSU(Smart Start Unit)																																	
AXELAMAZDA3	2.5L PY	F_BCM(Front Body Control Module)																																	
AXELAMAZDA3	2.5L PY	R_BCM(Rear Body Control Module)																																	
AXELAMAZDA3	2.5L PY	SCBS(Smart City Brake Support)																																	
AXELAMAZDA3	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
AXELAMAZDA3	2.5L PY	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.5L PY	CMU(Connectivity Master Unit)																																	
AXELAMAZDA3	2.5L PY	BSML(Blind Spot Monitoring Left)																																	
AXELAMAZDA3	2.5L PY	BSMR(Blind Spot Monitoring Right)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	PCM(Powertrain Control Module)							V	V	V	V	V	V	V	V	V	V	V	V	V	V													
AXELAMAZDA3	2.0L RF_T (Diesel)	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)								V	V	V	V	V	V	V		V			V	V													
AXELAMAZDA3	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	RCM(Restraint Control Module)						V																											
AXELAMAZDA3	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.2L SH (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.2L SH (Diesel)	PCM(Powertrain Control Module)							V		V		V	V	V																				
AXELAMAZDA3	2.2L SH (Diesel)	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	4x4(4x4 Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.2L SH (Diesel)	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.2L SH (Diesel)	CMU(Connectivity Master Unit)																																	
AXELAMAZDA3	2.2L SH (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.2L SH (Diesel)	AM(Amplifier Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	AFS(Adaptive Front Lighting System)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
AXELAMAZDA3	2.2L SH (Diesel)	DSM(Drivers Seat Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	DCDC(DC to DC Converter Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	FSC(Forward Sensing Camera)																																	
AXELAMAZDA3	2.2L SH (Diesel)	SCBS(Smart City Brake Support)																																	
AXELAMAZDA3	2.2L SH (Diesel)	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
AXELAMAZDA3	2.2L SH (Diesel)	EPB(Electonic Parking Brake)																																	
AXELAMAZDA3	2.2L SH (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.2L SH (Diesel)	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.2L SH (Diesel)	RVM(Rear Vehicle Monitoring)																																	
AXELAMAZDA3	2.2L SH (Diesel)	RCM(Restraint Control Module)						V																											
AXELAMAZDA3	2.2L SH (Diesel)	SSU(Smart Start Unit)																																	
AXELAMAZDA3	2.2L SH (Diesel)	F_BCM(Front Body Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	R_BCM(Rear Body Control Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	SYSTEM SEARCH																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	PCM(Powertrain Control Module)																						V		V		V	V	V		V	V	V	V
PREMACYMAZDA5	1.6L Y6 (BETA)	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	EPS(Electronic-Controlled Power Steering)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	IC(Instrument Cluster)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	LPSDM(Left Power Sliding Module)				V	V																												
PREMACYMAZDA5	1.6L Y6 (BETA)	RCM(Restraint Control Module)						V																											
PREMACYMAZDA5	1.6L Y6 (BETA)	RKE(Remote Keyless Entry)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	RPSDM(Right Power Sliding Module)				V	V																												
PREMACYMAZDA5	1.6L Y6 (BETA)	ACU(Audio Control Unit)																																	
PREMACYMAZDA5	1.8L (BETA)	2005	SYSTEM SEARCH																																
PREMACYMAZDA5	1.8L (BETA)	2005	PCM(Powertrain Control Module)-MT																																
PREMACYMAZDA5	1.8L (BETA)	2005	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	1.8L (BETA)	2005	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	1.8L (BETA)	2005	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	1.8L (BETA)	2005	GEM(Generic Electronic Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	RCM(Restraint Control Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	IC(Instrument Cluster)																																
PREMACYMAZDA5	1.8L (BETA)	2005	LPSDM(Left Power Sliding Module)			V	V																												
PREMACYMAZDA5	1.8L (BETA)	2005	RPSDM(Right Power Sliding Module)			V	V																												
PREMACYMAZDA5	1.8L (BETA)	2005	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	1.8L (BETA)	2005	PATS(Passive anti theft system)-Beta																																
PREMACYMAZDA5	2.0L LF	2005	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2005	PCM(Powertrain Control Module)	ALL																															
PREMACYMAZDA5	2.0L LF	2005	PCM(Powertrain Control Module)	AT																															
PREMACYMAZDA5	2.0L LF	2005	ABS(Anti-Lock Brake System)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
PREMACYMAZDA5	2.0L LF	2005	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.0L LF	2005	GEM(Generic Electronic Module)																																
PREMACYMAZDA5	2.0L LF	2005	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.0L LF	2005	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L LF	2005	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L LF	2005	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L LF	2005	PATS(Passive anti theft system)-Beta																																
PREMACYMAZDA5	2.0L LF	2007	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2007	PCM(Powertrain Control Module)																																
PREMACYMAZDA5	2.0L LF	2007	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	2.0L LF	2007	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.0L LF	2007	GEM(Generic Electronic Module)																																
PREMACYMAZDA5	2.0L LF	2007	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.0L LF	2007	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L LF	2007	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L LF	2007	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L LF	2007	PATS(Passive anti theft system)-Beta																																
PREMACYMAZDA5	2.0L LF	2010~	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2010~	PCM(Powertrain Control Module)																																
PREMACYMAZDA5	2.0L LF	2010~	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	2.0L LF	2010~	BCM/GEM(Body Control Module/Generic Electronic Module)																																
PREMACYMAZDA5	2.0L LF	2010~	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L LF	2010~	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.0L LF	2010~	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L LF	2010~	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L LF	2010~	LPSDM(Left Power Sliding Module)			V	V																												
PREMACYMAZDA5	2.0L LF	2010~	RCM(Restraint Control Module)					V																											
PREMACYMAZDA5	2.0L LF	2010~	RPSDM(Right Power Sliding Module)			V	V																												
PREMACYMAZDA5	2.0L LF	2010~	TCM(Transmission Control Module)																																
PREMACYMAZDA5	2.0L RF_T (Diesel)	SYSTEM SEARCH																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	PCM(Powertrain Control Module)							V	V	V	V	V	V	V	V	V	V	V	V	V	V													
PREMACYMAZDA5	2.0L RF_T (Diesel)	TCM(Transmission Control Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	GEM(Generic Electronic Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	IC(Instrument Cluster)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	RKE(Remote Keyless Entry)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
PREMACYMAZDA5	2.3L L3	SYSTEM SEARCH																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
PREMACYMAZDA5	2.3L L3	PCM(Powertrain Control Module)																																	
PREMACYMAZDA5	2.3L L3	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	2.3L L3	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	2.3L L3	EPS(Electronic-Controlled Power Steering)																																	
PREMACYMAZDA5	2.3L L3	GEM(Generic Electronic Module)																																	
PREMACYMAZDA5	2.3L L3	IC(Instrument Cluster)																																	
PREMACYMAZDA5	2.3L L3	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	2.3L L3	TPM(Tire Pressure Monitor)																																	
PREMACYMAZDA5	2.5L L5	SYSTEM SEARCH																																	
PREMACYMAZDA5	2.5L L5	PCM(Powertrain Control Module)																																	
PREMACYMAZDA5	2.5L L5	TCM(Transmission Control Module)																																	
PREMACYMAZDA5	2.5L L5	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	2.5L L5	EPS(Electronic-Controlled Power Steering)																																	
PREMACYMAZDA5	2.5L L5	RCM(Restraint Control Module)						V																											
PREMACYMAZDA5	2.5L L5	IC(Instrument Cluster)																																	
PREMACYMAZDA5	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
PREMACYMAZDA5	2.5L L5	LPSDM(Left Power Sliding Module)				V	V																												
PREMACYMAZDA5	2.5L L5	RPSDM(Right Power Sliding Module)				V	V																												
PREMACYMAZDA5	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	2.5L L5	AFS(Adaptive Front Lighting System)																																	
PREMACYMAZDA5	2.5L L5	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	1.8L L8	SYSTEM SEARCH																																	
ATENZAMAZDA6	1.8L L8	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	1.8L L8	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	1.8L L8	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	1.8L L8	GEM(Generic Electronic Module)																																	
ATENZAMAZDA6	1.8L L8	IC(Instrument Cluster)																																	
ATENZAMAZDA6	1.8L L8	LHID(Left High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	1.8L L8	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	1.8L L8	RHID(Right High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	1.8L L8	RKE(Remote Keyless Entry)																																	
ATENZAMAZDA6	1.8L L8	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.0L PE	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.0L PE	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.0L PE	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.0L PE	4x4(4x4 Control Module)																																	
ATENZAMAZDA6	2.0L PE	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.0L PE	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.0L PE	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.0L PE	EPB(Electonic Parking Brake)																																	
ATENZAMAZDA6	2.0L PE	AM(Amplifier Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
ATENZAMAZDA6	2.0L PE	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.0L PE	DSM(Drivers Seat Module)																																	
ATENZAMAZDA6	2.0L PE	DCDC(DC to DC Converter Control Module)																																	
ATENZAMAZDA6	2.0L PE	FSC(Forward Sensing Camera)																																	
ATENZAMAZDA6	2.0L PE	SCBS(Smart City Brake Support)																																	
ATENZAMAZDA6	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
ATENZAMAZDA6	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.0L PE	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.0L PE	RVM(Rear Vehicle Monitoring)																																	
ATENZAMAZDA6	2.0L PE	RCM(Restraint Control Module)						V																											
ATENZAMAZDA6	2.0L PE	SSU(Smart Start Unit)																																	
ATENZAMAZDA6	2.0L PE	F_BCM(Front Body Control Module)																																	
ATENZAMAZDA6	2.0L PE	R_BCM(Rear Body Control Module)																																	
ATENZAMAZDA6	2.0L PE	CMU(Connectivity Master Unit)																																	
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.0L LF	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.0L LF	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.0L LF	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.0L LF	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.0L LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
ATENZAMAZDA6	2.0L LF	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.0L LF	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.0L LF	GEM(Generic Electronic Module)																																	
ATENZAMAZDA6	2.0L LF	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.0L LF	LCM(Lighting Control Module)																																	
ATENZAMAZDA6	2.0L LF	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.0L LF	RHID(Right High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.0L LF	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.0L LF	LHID(Left High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.0L LF	RKE(Remote Keyless Entry)																																	
ATENZAMAZDA6	2.0L LF	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.3L L3	2.3L	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3L	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3	2.3L	IC(Instrument Cluster)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
ATENZAMAZDA6	2.3L L3	2.3L	GEM(Generic Electronic Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	RHID(Right High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.3L L3	2.3L	LHID(Left High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.3L L3	2.3L	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.3L L3_T	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.3L L3_T	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.3L L3_T	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.3L L3_T	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.3L L3_T	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.3L L3_T	LHID(Left High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.3L L3_T	RHID(Right High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.3L L3_T	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.3L L3_T	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.5L L5	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.5L L5	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.5L L5	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.5L L5	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.5L L5	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.5L L5	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.5L L5	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
ATENZAMAZDA6	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
ATENZAMAZDA6	2.5L L5	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.5L L5	LCM(Lighting Control Module)																																	
ATENZAMAZDA6	2.5L L5	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.5L PY	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.5L PY	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.5L PY	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.5L PY	4x4(4x4 Control Module)																																	
ATENZAMAZDA6	2.5L PY	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.5L PY	AM(Amplifier Module)																																	
ATENZAMAZDA6	2.5L PY	BSML(Blind Spot Monitoring Left)																																	
ATENZAMAZDA6	2.5L PY	BSMR(Blind Spot Monitoring Right)																																	
ATENZAMAZDA6	2.5L PY	DSM(Drivers Seat Module)																																	
ATENZAMAZDA6	2.5L PY	DCDC(DC to DC Converter Control Module)																																	
ATENZAMAZDA6	2.5L PY	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.5L PY	EPB(Electonic Parking Brake)																																	
ATENZAMAZDA6	2.5L PY	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.5L PY	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.5L PY	RCM(Restraint Control Module)						V																											
ATENZAMAZDA6	2.5L PY	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.5L PY	FSC(Forward Sensing Camera)																																	
ATENZAMAZDA6	2.5L PY	SSU(Smart Start Unit)																																	
ATENZAMAZDA6	2.5L PY	F_BCM(Front Body Control Module)																																	
ATENZAMAZDA6	2.5L PY	R_BCM(Rear Body Control Module)																																	
ATENZAMAZDA6	2.5L PY	SCBS(Smart City Brake Support)																																	
ATENZAMAZDA6	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
ATENZAMAZDA6	2.5L PY	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.5L PY	CMU(Connectivity Master Unit)																																	
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	FFH(Fuel Fired Coolant Heating Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	LHID(Left High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	RHID(Right High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	PCM(Powertrain Control Module)						V	V	V	V	V	V	V	V	V	V	V	V	V	V		V											
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	ACU(Audio Control Unit)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	BCM/GEM(Body Control Module/Generic Electronic Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	GEM(Generic Electronic Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	EATC(Electronic Automatic Temperature Control)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	EPS(Electronic-Controlled Power Steering)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	FFH(Fuel Fired Coolant Heating Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	LCM(Lighting Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	RVM(Rear Vehicle Monitoring)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)							V	V	V	V	V	V	V	V		V			V			V											
ATENZAMAZDA6	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	LCM(Lighting Control Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.2L SH (Diesel)	PCM(Powertrain Control Module)							V		V		V	V	V																				
ATENZAMAZDA6	2.2L SH (Diesel)	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	4x4(4x4 Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	AM(Amplifier Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	CMU(Connectivity Master Unit)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	DSM(Drivers Seat Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	DCDC(DC to DC Converter Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	FSC(Forward Sensing Camera)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SCBS(Smart City Brake Support)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	EPB(Electonic Parking Brake)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	RVM(Rear Vehicle Monitoring)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	RCM(Restraint Control Module)						V																											
ATENZAMAZDA6	2.2L SH (Diesel)	SSU(Smart Start Unit)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	F_BCM(Front Body Control Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
ATENZAMAZDA6	2.2L SH (Diesel)	R_BCM(Rear Body Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	BSM(Blind Spot Monitoring)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	PSM(Parking Sensor Module)																																	
MPVMAZDA8	2.3L L3	SYSTEM SEARCH																																	
MPVMAZDA8	2.3L L3	PCM(Powertrain Control Module)																																	
MPVMAZDA8	2.3L L3	ABS(Anti-Lock Brake System)																																	
MPVMAZDA8	2.3L L3_T	SYSTEM SEARCH																																	
MPVMAZDA8	2.3L L3_T	PCM(Powertrain Control Module)																																	
MPVMAZDA8	2.3L L3_T	ABS(Anti-Lock Brake System)																																	
MPVMAZDA8	2.3L L3_T	AM(Amplifier Module)																																	
MPVMAZDA8	2.3L L3_T	GEM(Generic Electronic Module)																																	
MPVMAZDA8	2.3L L3_T	HCM(Headlamp Control Module)																																	
MPVMAZDA8	2.3L L3_T	ICCM(Intelligent Cruise Control Module)-Beta Test																																	
MPVMAZDA8	2.3L L3_T	IC(Instrument Cluster)																																	
MPVMAZDA8	2.3L L3_T	LTM(Liftgate/Trunk Module)-Beta Test																																	
MPVMAZDA8	2.3L L3_T	RCM(Restraint Control Module)																																	
MPVMAZDA8	2.3L L3_T	RKE(Remote Keyless Entry)																																	
MPVMAZDA8	2.3L L3_T	TCM(Transmission Control Module)																																	
MPVMAZDA8	2.3L L3_T	LCM(Lighting Control Module)-Beta Test																																	
MPVMAZDA8	2.3L L3_T	4x4(4x4 Control Module)																																	
MPVMAZDA8	2.3L L3_T	LPSDM(Left Power Sliding Door Module)																																	
MPVMAZDA8	2.3L L3_T	RPSDM(Right Power Sliding Door Module)																																	
ROADSTERMX-5	North America/General specs	2.0L LF	SYSTEM SEARCH																																
ROADSTERMX-5	North America/General specs	2.0L LF	PCM(Powertrain Control Module)	2006~																															
ROADSTERMX-5	North America/General specs	2.0L LF	PCM(Powertrain Control Module)	2008~																															
ROADSTERMX-5	North America/General specs	2.0L LF	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	North America/General specs	2.0L LF	IC(Instrument Cluster)			V																													
ROADSTERMX-5	North America/General specs	2.0L LF	RCM(Restraint Control Module)																																
ROADSTERMX-5	North America/General specs	2.0L LF	RHT(Retractable Hard Top)																																
ROADSTERMX-5	North America/General specs	2.0L LF	RKE(Remote Keyless Entry)																																
ROADSTERMX-5	North America/General specs	2.0L LF	TCM(Transmission Control Module)																																
ROADSTERMX-5	North America/General specs	2.0L LF	PATS(Passive anti theft system)-Beta																																
ROADSTERMX-5	North America/General specs	2.0L LF	DHS(Deployable Hood System)																																
ROADSTERMX-5	North America/General specs	1.5L P5	SYSTEM SEARCH																																
ROADSTERMX-5	North America/General specs	1.5L P5	PCM(Powertrain Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	North America/General specs	1.5L P5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	AM(Amplifier Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	DCDC(DC to DC Converter Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	EATC(Electronic Automatic Temperature Control)																																
ROADSTERMX-5	North America/General specs	1.5L P5	EPS(Electronic-Controlled Power Steering)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
ROADSTERMX-5	North America/General specs	1.5L P5	EVP(Electronical VACUUM PUMP)																																
ROADSTERMX-5	North America/General specs	1.5L P5	IC(Instrument Cluster)																																
ROADSTERMX-5	North America/General specs	1.5L P5	RCM(Restraint Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	TCM(Transmission Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	BSM(Blind Spot Monitoring)																																
ROADSTERMX-5	North America/General specs	1.5L P5	BCM(Body Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	FSC(Forward Sensing Camera)																																
ROADSTERMX-5	North America/General specs	1.5L P5	SSU(Smart Start Unit)																																
ROADSTERMX-5	North America/General specs	1.5L P5	CMU(Connectivity Master Unit)																																
ROADSTERMX-5	North America/General specs	1.5L P5	ESU(Electric Supply Unit)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	PCM(Powertrain Control Module)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	IC(Instrument Cluster)			V																													
ROADSTERMX-5	Europe/General Specs	2.0L LF	RCM(Restraint Control Module)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	RHT(Retractable Hard Top)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	RKE(Remote Keyless Entry)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	TCM(Transmission Control Module)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	PATS(Passive anti theft system)-Beta																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	DHS(Deployable Hood System)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	PCM(Powertrain Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	IC(Instrument Cluster)			V																													
ROADSTERMX-5	Europe/General Specs	1.8L L8	RCM(Restraint Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	RHT(Retractable Hard Top)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	RKE(Remote Keyless Entry)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	TCM(Transmission Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	PATS(Passive anti theft system)-Beta																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	PCM(Powertrain Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	AM(Amplifier Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	DCDC(DC to DC Converter Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	EATC(Electronic Automatic Temperature Control)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	EPS(Electronic-Controlled Power Steering)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	EVP(Electronical VACUUM PUMP)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	IC(Instrument Cluster)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	RCM(Restraint Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	TCM(Transmission Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
ROADSTERMX-5	Europe/General Specs	1.5L P5	BSM(Blind Spot Monitoring)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	BCM(Body Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	FSC(Forward Sensing Camera)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	SSU(Smart Start Unit)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	CMU(Connectivity Master Unit)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	ESU(Electric Supply Unit)																																
RX-8	North America Spec	13B	SYSTEM SEARCH																																
RX-8	North America Spec	13B	PCM(Powertrain Control Module)																																
RX-8	North America Spec	13B	PATS(Passive anti theft system)-Beta																																
RX-8	North America Spec	13B	ABS(Anti-Lock Brake System)																																
RX-8	North America Spec	13B	EPS(Electronic-Controlled Power Steering)																																
RX-8	North America Spec	13B	IC(Instrument Cluster)																																
RX-8	North America Spec	13B	RCM(Restraint Control Module)																																
RX-8	North America Spec	13B	RKE(Remote Keyless Entry)																																
RX-8	North America Spec	13B	TCM(Transmission Control Module)																																
RX-8	North America Spec	13B	TPM(Tire Pressure Monitor)																																
RX-8	North America Spec	13B	LCM(Lighting Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	SYSTEM SEARCH																																
RX-8	North America Spec	13B-MSP High-Power	PCM(Powertrain Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	PATS(Passive anti theft system)-Beta																																
RX-8	North America Spec	13B-MSP High-Power	ABS(Anti-Lock Brake System)																																
RX-8	North America Spec	13B-MSP High-Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	North America Spec	13B-MSP High-Power	IC(Instrument Cluster)																																
RX-8	North America Spec	13B-MSP High-Power	RCM(Restraint Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	RKE(Remote Keyless Entry)																																
RX-8	North America Spec	13B-MSP High-Power	TCM(Transmission Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	TPM(Tire Pressure Monitor)																																
RX-8	North America Spec	13B-MSP Standard-Power	SYSTEM SEARCH																																
RX-8	North America Spec	13B-MSP Standard-Power	PCM(Powertrain Control Module)																																
RX-8	North America Spec	13B-MSP Standard-Power	PATS(Passive anti theft system)-Beta																																
RX-8	North America Spec	13B-MSP Standard-Power	ABS(Anti-Lock Brake System)																																
RX-8	North America Spec	13B-MSP Standard-Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	North America Spec	13B-MSP Standard-Power	IC(Instrument Cluster)																																
RX-8	North America Spec	13B-MSP Standard-Power	RCM(Restraint Control Module)																																
RX-8	North America Spec	13B-MSP Standard-Power	RKE(Remote Keyless Entry)																																
RX-8	North America Spec	13B-MSP Standard-Power	TCM(Transmission Control Module)																																
RX-8	North America Spec	13B-MSP Standard-Power	TPM(Tire Pressure Monitor)																																
RX-8	General	13B	SYSTEM SEARCH																																
RX-8	General	13B	PCM(Powertrain Control Module)																																
RX-8	General	13B	PATS(Passive anti theft system)-Beta																																
RX-8	General	13B	ABS(Anti-Lock Brake System)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
RX-8	General	13B	EPS(Electronic-Controlled Power Steering)																																
RX-8	General	13B	IC(Instrument Cluster)																																
RX-8	General	13B	RCM(Restraint Control Module)																																
RX-8	General	13B	RKE(Remote Keyless Entry)																																
RX-8	General	13B	TCM(Transmission Control Module)																																
RX-8	General	13B MSP High Power	SYSTEM SEARCH																																
RX-8	General	13B MSP High Power	PCM(Powertrain Control Module)																																
RX-8	General	13B MSP High Power	PATS(Passive anti theft system)-Beta																																
RX-8	General	13B MSP High Power	ABS(Anti-Lock Brake System)																																
RX-8	General	13B MSP High Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	General	13B MSP High Power	IC(Instrument Cluster)																																
RX-8	General	13B MSP High Power	RCM(Restraint Control Module)																																
RX-8	General	13B MSP High Power	RKE(Remote Keyless Entry)																																
RX-8	General	13B MSP High Power	TCM(Transmission Control Module)																																
RX-8	General	13B MSP Standard Power	SYSTEM SEARCH																																
RX-8	General	13B MSP Standard Power	PCM(Powertrain Control Module)																																
RX-8	General	13B MSP Standard Power	PATS(Passive anti theft system)-Beta																																
RX-8	General	13B MSP Standard Power	ABS(Anti-Lock Brake System)																																
RX-8	General	13B MSP Standard Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	General	13B MSP Standard Power	IC(Instrument Cluster)																																
RX-8	General	13B MSP Standard Power	RCM(Restraint Control Module)																																
RX-8	General	13B MSP Standard Power	RKE(Remote Keyless Entry)																																
RX-8	General	13B MSP Standard Power	TCM(Transmission Control Module)																																
ESCAPETRIBUTE	Up to 2004	SYSTEM SEARCH																																	
ESCAPETRIBUTE	Up to 2004	PCM(PowerTrain Control Module)																																	
ESCAPETRIBUTE	Up to 2004	Immobilizer																																	
ESCAPETRIBUTE	Up to 2004	ABS(Anti-Lock Brake System)																																	
ESCAPETRIBUTE	Up to 2004	RCM(Restraint Control Module)																																	
ESCAPETRIBUTE	Up to 2004	GEM(Generic Electronic Module)																																	
ESCAPETRIBUTE	From 2004	SYSTEM SEARCH																																	
ESCAPETRIBUTE	From 2004	PCM(PowerTrain Control Module)																																	
ESCAPETRIBUTE	From 2004	PATS(Passive anti theft system)																																	
ESCAPETRIBUTE	From 2004	ABS(Anti-Lock Brake System)																																	
ESCAPETRIBUTE	From 2004	RCM(Restraint Control Module)																																	
ESCAPETRIBUTE	From 2004	IC(Instrument Cluster)																																	
ESCAPETRIBUTE	From 2004	GEM(Generic Electronic Module)																																	
General(ALL Model)	16PIN CONNECTOR	SYSTEM SEARCH																																	
General(ALL Model)	16PIN CONNECTOR	PCM(PowerTrain Control Module)																																	
General(ALL Model)	16PIN CONNECTOR	PATS(Passive anti theft system)-Beta																																	
General(ALL Model)	16PIN CONNECTOR	TCM(Transmission Control Module)																																	
General(ALL Model)	16PIN CONNECTOR	ABS(Anti-Lock Brake System)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
General(ALL Model)	16PIN CONNECTOR	RCM(Restraint Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	SYSTEM SEARCH																																	
General(ALL Model)	17PIN CONNECTOR	PCM(PowerTrain Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	TCM(Transmission Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	ABS(Anti-Lock Brake System)																																	
General(ALL Model)	17PIN CONNECTOR	RCM(Restraint Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	PCM(PowerTrain Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	TCM(Transmission Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	RCM(Restraint Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ABS(Anti-Lock Brake System)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ACCM(Air Conditioning Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	4WS(4 Wheel Steering)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ICCM(Intelligent Cruise Control Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RKE(Remote Keyless Entry)(WithSKE)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RKE(Remote Keyless Entry)(WIthout SKE)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	VSM(Vehicle Security Module)																																
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	ASM																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	AT																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	PowerShift																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	RCM(Restraint Control Module)				V																											
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	RCM(Restraint Control Module)				V																											
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 (Low Power without DPF)	ASM																														

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 (Low Power without DPF)	ALL																			V											
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 + DPF (High Power with DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 3(High Power without DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	RCM(Restraint Control Module)				V																											
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 4(Low Power without DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 4 + DPF (High Power with DPF)																				V		V									
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 3(High Power without DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	PCM(Powertrain Control Module)																				V		V									
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	FACM(Fuel Additive Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	RCM(Restraint Control Module)				V																											
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	1.6 Z6	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	GEM(Generic Electronic Module)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	RCM(Restraint Control Module)					V																											
BETA-ETC	MAZDA 3 EURO	1.6 Z6	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	ASM																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	AT																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	PowerShift																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	RCM(Restraint Control Module)				V																											

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	RCM(Restraint Control Module)				V																											
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	PCM(Powertrain Control Module)					V	V	V	V	V	V	V	V	V	V	V	V	V			V											
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	FFH(Fuel Fired Coolant Heating Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	RCM(Restraint Control Module)				V																											
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	ASM																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	AT																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	PowerShift																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	RCM(Restraint Control Module)				V																											
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	RCM(Restraint Control Module)				V																											
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA GASOLINE ENGINE	PCM(Powertrain Control Module)																																	
BETA-ETC	MAZDA DIESEL ENGINE	PCM(Powertrain Control Module)							V	V	V	V	V	V	V	V	V	V	V	V	V	V		V											
BETA-ETC	MAZDA 2 ENGINE	PCM(Powertrain Control Module)																																	
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	ABS(Anti-Lock Brake System)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	RCM(Restraint Control Module)																																
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	SYSTEM SEARCH																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	PCM(Powertrain Control Module)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	ABS(Anti-Lock Brake System)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	EPS(Electronic-Controlled Power Steering)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	IC(Instrument Cluster)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	4x4(4x4 Control Module)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	RCM(Restraint Control Module)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	RKE(Remote Keyless Entry)																																	
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	SYSTEM SEARCH																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	PCM(Powertrain Control Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	ABS(Anti-Lock Brake System)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	IC(Instrument Cluster)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	RCM(Restraint Control Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	RKE(Remote Keyless Entry)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	VSM(Vehicle Security Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	TCM(Transmission Control Module)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	EPS(Electronic-Controlled Power Steering)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	GEM(Generic Electronic Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	RCM(Restraint Control Module)				V																											
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	RKE(Remote Keyless Entry)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	RKE(Remote Keyless Entry)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	TCM(Transmission Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	RCM(Restraint Control Module)				V																											
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	MID(Multi-Information Display)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	PCM(Powertrain Control Module)					V	V	V	V	V	V	V		V			V	V														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	RCM(Restraint Control Module)				V																											
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	MID(Multi-Information Display)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	EATC(Electronic Automatic Temperature Control)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	ABS(Anti-Lock Brake System)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	RKE(Remote Keyless Entry)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	TCM(Transmission Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	SYSTEM SEARCH																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	PCM(Powertrain Control Module)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	IC(Instrument Cluster)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 3 (North America/General)	SYSTEM SEARCH																																	
BETA-ETC	MAZDA 3 (North America/General)	PCM(Powertrain Control Module)																																	
BETA-ETC	MAZDA 3 (North America/General)	ABS(Anti-Lock Brake System)																																	
BETA-ETC	MAZDA 3 (North America/General)	IC(Instrument Cluster)																																	
BETA-ETC	MAZDA 3 (North America/General)	TPM(Tire Pressure Monitor)																																	
BETA-ETC	MAZDA 3 (China/General)	1.6L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	RKE(Remote Keyless Entry)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	SYSTEM SEARCH																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	PCM(Powertrain Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	ABS(Anti-Lock Brake System)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	IC(Instrument Cluster)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	GEM(Generic Electronic Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RCM(Restraint Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	LPSDM(Left Power Sliding Door Module)			V	V																												
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RPSDM(Right Power Sliding Door Module)			V	V																												
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	TCM(Transmission Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RKE(Remote Keyless Entry)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	PCM(Powertrain Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	ABS(Anti-Lock Brake System)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	IC(Instrument Cluster)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	GEM(Generic Electronic Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RCM(Restraint Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	LPSDM(Left Power Sliding Door Module)			V	V																												
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RPSDM(Right Power Sliding Door Module)			V	V																												
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	TCM(Transmission Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	TPM(Tire Pressure Monitor)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	PCM(Powertrain Control Module)	ALL																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	LHID(Left High Intensity Discharge Lamp)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	PCM(Powertrain Control Module)	ALL																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	PCM(Powertrain Control Module)						V	V	V	V	V	V	V	V	V	V	V	V	V			V											
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	GEM(Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	LHID(Left High Intensity Discharge Lamp)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RHID(Right High Intensity Discharge Lamp)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	TCM(Transmission Control Module)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	SYSTEM SEARCH																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	PCM(Powertrain Control Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	ABS(Anti-Lock Brake System)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	GEM(Generic Electronic Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	IC(Instrument Cluster)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	LHID(Left High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RHID(Right High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RCM(Restraint Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RKE(Remote Keyless Entry)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	TCM(Transmission Control Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	SYSTEM SEARCH																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	PCM(Powertrain Control Module)	ALL																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	PCM(Powertrain Control Module)	MT					V	V	V	V	V	V	V	V		V			V			V											
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	GEM(Generic Electronic Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	LHID(Left High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RHID(Right High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	IC(Instrument Cluster)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RCM(Restraint Control Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RKE(Remote Keyless Entry)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	PCM(Powertrain Control Module)						V	V	V	V	V	V	V	V	V	V	V	V	V			V											
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	IC(Instrument Cluster)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	PCM(Powertrain Control Module)						V	V	V	V	V	V	V	V		V			V			V											
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	FFH(Fuel Fired Coolant Heating Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	PCM(Powertrain Control Module)-ALL																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	TPM(Tire Pressure Monitor)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	TPM(Tire Pressure Monitor)																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	PCM(Powertrain Control Module)						V	V	V	V	V	V	V	V	V	V	V	V	V			V											
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	FFH(Fuel Fired Coolant Heating Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	RCM(Restraint Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	GEM(Generic Electronic Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	HCM(Headlamp Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	ICCM(Intelligent Cruise Control Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	IC(Instrument Cluster)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	LTM(Liftgate/Trunk Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	RCM(Restraint Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	RKE(Remote Keyless Entry)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	GEM(Generic Electronic Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	HCM(Headlamp Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	ICCM(Intelligent Cruise Control Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	IC(Instrument Cluster)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LTM(Liftgate/Trunk Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RCM(Restraint Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RKE(Remote Keyless Entry)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LCM(Lighting Control Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	4x4(4x4 Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LPSDM(Left Power Sliding Door Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RPSDM(Right Power Sliding Door Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Freeze Frame Data	I/O Signal Monitor	RCM Module Installation	DPF Reset	DPF Assessment	DPF Regeneration	PCM Data Reset	Engine oil reset	Fuel pump reset	Injector reset	MAF sensor reset	O2/Air Fuel Ratio (A/F) Sensor	DPF Pressure sensor reset	DPF Data Reset	ETB/EGR Reset	ETB/EGR Initialization	Fuel Injector Correction Factors	Injection Amount Correction	Fuel injector correction factors	Mileage After injectors Replacement	DPF Static Regeneration	Reset KAM	Reset the Intake Air Throttle Valve Learned Values	Reset the Exhaust Gas Recirculation Valve Learned Values	Reset the Diesel Particulate Filter Learned Values	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values	Reset the water in fuel Warning Indicator	Reset the Powertrain Control Module Learned Valus	Reset the Exhaust Gas Temperature Value	Reset the High Pressure Fuel System Learned Values
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	SYSTEM SEARCH																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	PCM(Powertrain Control Module)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	ABS(Anti-Lock Brake System)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	IC(Instrument Cluster)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	TCM(Transmission Control Module)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	SYSTEM SEARCH																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	2005~					V	V	V	V	V	V	V	V	V	V	V	V	V	V	V												
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	~2005																				V	V										
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	TCM(Transmission Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	SYSTEM SEARCH																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	PCM(Powertrain Control Module)													V																			
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	ABS(Anti-Lock Brake System)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	RCM(Restraint Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	TCM(Transmission Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	SYSTEM SEARCH																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	PCM(Powertrain Control Module)													V																			
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	ABS(Anti-Lock Brake System)																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	TCM(Transmission Control Module)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	PCM(Powertrain Control Module)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	ABS(Anti-Lock Brake System)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	GEM(Generic Electronic Module)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	IC(Instrument Cluster)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	RCM(Restraint Control Module)																																
BETA-ETC	TITAN DASH	2.0L RF_T	SYSTEM SEARCH																																
BETA-ETC	TITAN DASH	2.0L RF_T	PCM(Powertrain Control Module)																					V	V										
BETA-ETC	TITAN DASH	2.0L RF_T	TCM(Transmission Control Module)																																
BETA-ETC	PATS(Passive anti theft system)																																		
BETA-ETC	Vehicle Log Capture																																		

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
Incode Calculator	Incode Calculator	~2010.05																																	
Service Manual	Reset the Oil Change Indicator(G-scan Support)																																		
Service Manual	Oil Light Reset / Service Light Reset(Manual)																																		
Service Manual	Throttle Body Learning																																		
BIANTE	2.0L LF	SYSTEM SEARCH																																	
BIANTE	2.0L LF	PCM(Powertrain Control Module)																																	
BIANTE	2.0L LF	ABS(Anti-Lock Brake System)																																	
BIANTE	2.0L LF	EATC(Electronic Automatic Temperature Control)																																	
BIANTE	2.0L LF	EPS(Electronic-Controlled Power Steering)																																	
BIANTE	2.0L LF	GEM(Generic Electronic Module)																																	
BIANTE	2.0L LF	IC(Instrument Cluster)																																	
BIANTE	2.0L LF	LPSDM(Left Power Sliding Door Module)																																	
BIANTE	2.0L LF	RCM(Restraint Control Module)																																	
BIANTE	2.0L LF	RKE(Remote Keyless Entry)																																	
BIANTE	2.0L LF	RPSDM(Right Power Sliding Door Module)																																	
BIANTE	2.0L LF	TCM(Transmission Control Module)																																	
BIANTE	2.3L L3	SYSTEM SEARCH																																	
BIANTE	2.3L L3	PCM(Powertrain Control Module)																																	
BIANTE	2.3L L3	ABS(Anti-Lock Brake System)																																	
BIANTE	2.3L L3	EATC(Electronic Automatic Temperature Control)																																	
BIANTE	2.3L L3	EPS(Electronic-Controlled Power Steering)																																	
BIANTE	2.3L L3	GEM(Generic Electronic Module)																																	
BIANTE	2.3L L3	IC(Instrument Cluster)																																	
BIANTE	2.3L L3	LPSDM(Left Power Sliding Door Module)																																	
BIANTE	2.3L L3	RCM(Restraint Control Module)																																	
BIANTE	2.3L L3	RKE(Remote Keyless Entry)																																	
BIANTE	2.3L L3	RPSDM(Right Power Sliding Door Module)																																	
BIANTE	2.3L L3	TCM(Transmission Control Module)																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	SYSTEM SEARCH																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	2005~																																
BONGOBRAWNYSPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	~2005																																
BONGOBRAWNYSPECTRON	2.0L RF_T	ABS(Anti-Lock Brake System)																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.2 Diesel	SYSTEM SEARCH																																	
BT-50(RANGER)	2.2 Diesel	PCM(PowerTrain Control Module)				V	V	V	V																										
BT-50(RANGER)	2.2 Diesel	ABS(Anti-Lock Brake System)								V	V	V																							
BT-50(RANGER)	2.2 Diesel	ACM(Audio Control Module)											V																						
BT-50(RANGER)	2.2 Diesel	BCMii(Body Control Module)																																	
BT-50(RANGER)	2.2 Diesel	DDM(Drivers Door Module)																																	
BT-50(RANGER)	2.2 Diesel	FCDIM(Front Control/Display Interface Module)																																	
BT-50(RANGER)	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BT-50(RANGER)	2.2 Diesel	IPC(Instrument Panel Control Module)																																	
BT-50(RANGER)	2.2 Diesel	PAM(Parking Aid Module)																																	
BT-50(RANGER)	2.2 Diesel	PDM(Passengers Door Module)																																	
BT-50(RANGER)	2.2 Diesel	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.2 Diesel	SRM(Speech Recognition Module)																																	
BT-50(RANGER)	2.2 Diesel	TBM(Tracking And Blocking Module)												V	V																				
BT-50(RANGER)	2.2 Diesel	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.2 Diesel	TRM(Trailer Module)																																	
BT-50(RANGER)	2.2 Diesel	PATS(Passive anti theft system)														V	V	V																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																	V	V															
BT-50(RANGER)	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																			V														
BT-50(RANGER)	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																			V														
BT-50(RANGER)	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)														V	V	V																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																	V	V		V													
BT-50(RANGER)	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																			V														
BT-50(RANGER)	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																			V														
BT-50(RANGER)	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)														V	V	V																	
BT-50(RANGER)	3.2 Diesel	SYSTEM SEARCH																																	
BT-50(RANGER)	3.2 Diesel	PCM(PowerTrain Control Module)				V	V	V	V																										
BT-50(RANGER)	3.2 Diesel	ABS(Anti-Lock Brake System)								V	V	V																							
BT-50(RANGER)	3.2 Diesel	ACM(Audio Control Module)											V																						
BT-50(RANGER)	3.2 Diesel	BCMii(Body Control Module)																																	
BT-50(RANGER)	3.2 Diesel	DDM(Drivers Door Module)																																	
BT-50(RANGER)	3.2 Diesel	FCDIM(Front Control/Display Interface Module)																																	
BT-50(RANGER)	3.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																	
BT-50(RANGER)	3.2 Diesel	IPC(Instrument Panel Control Module)																																	
BT-50(RANGER)	3.2 Diesel	PAM(Parking Aid Module)																																	
BT-50(RANGER)	3.2 Diesel	PDM(Passengers Door Module)																																	
BT-50(RANGER)	3.2 Diesel	RCM(Restraint Control Module)																																	
BT-50(RANGER)	3.2 Diesel	SRM(Speech Recognition Module)																																	
BT-50(RANGER)	3.2 Diesel	TBM(Tracking And Blocking Module)												V	V																				
BT-50(RANGER)	3.2 Diesel	TCM(Transmission Control Module)																																	
BT-50(RANGER)	3.2 Diesel	TRM(Trailer Module)																																	
BT-50(RANGER)	3.2 Diesel	PATS(Passive anti theft system)														V	V	V																	
BT-50(RANGER)	2.3 Gasoline	PCM(Powertrain Control Module)																					V	V	V	V									
BT-50(RANGER)	2.3 Gasoline	ABS(Anti-Lock Brake System)								V											V														
BT-50(RANGER)	2.3 Gasoline	GEM(Generic Electronic Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BT-50(RANGER)	2.3 Gasoline	IC(Instrument Cluster)																																	
BT-50(RANGER)	2.3 Gasoline	OCSM(Occupant Classification System Module)																									V								
BT-50(RANGER)	2.3 Gasoline	4x4(4x4 Control Module)																																	
BT-50(RANGER)	2.3 Gasoline	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.3 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																	
BT-50(RANGER)	2.3 Gasoline	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	2.5 Gasoline	PCM(PowerTrain Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	ABS(Anti-Lock Brake System)								V	V	V																							
BT-50(RANGER)	2.5 Gasoline	ACM(Audio Control Module)											V																						
BT-50(RANGER)	2.5 Gasoline	BCMii(Body Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	DDM(Drivers Door Module)																																	
BT-50(RANGER)	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																																	
BT-50(RANGER)	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																																	
BT-50(RANGER)	2.5 Gasoline	IPC(Instrument Panel Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	PAM(Parking Aid Module)																																	
BT-50(RANGER)	2.5 Gasoline	PDM(Passengers Door Module)																																	
BT-50(RANGER)	2.5 Gasoline	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	SRM(Speech Recognition Module)																																	
BT-50(RANGER)	2.5 Gasoline	TBM(Tracking And Blocking Module)												V	V																				
BT-50(RANGER)	2.5 Gasoline	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	TRM(Trailer Module)																																	
BT-50(RANGER)	2.5 Gasoline	PATS(Passive anti theft system)														V	V	V																	
BT-50(RANGER)	3.0 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	3.0 Gasoline	PCM(Powertrain Control Module)																					V	V	V	V									
BT-50(RANGER)	3.0 Gasoline	ABS(Anti-Lock Brake System)								V											V														
BT-50(RANGER)	3.0 Gasoline	GEM(Generic Electronic Module)																																	
BT-50(RANGER)	3.0 Gasoline	IC(Instrument Cluster)																																	
BT-50(RANGER)	3.0 Gasoline	OCSM(Occupant Classification System Module)																									V								
BT-50(RANGER)	3.0 Gasoline	4x4(4x4 Control Module)																																	
BT-50(RANGER)	3.0 Gasoline	RCM(Restraint Control Module)																																	
BT-50(RANGER)	3.0 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																	
BT-50(RANGER)	3.0 Gasoline	TCM(Transmission Control Module)																																	
BT-50(RANGER)	4.0 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	4.0 Gasoline	PCM(Powertrain Control Module)																																	
BT-50(RANGER)	4.0 Gasoline	ABS(Anti-Lock Brake System)								V																		V							
BT-50(RANGER)	4.0 Gasoline	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																	
BT-50(RANGER)	4.0 Gasoline	IC(Instrument Cluster)																																	
BT-50(RANGER)	4.0 Gasoline	OCSM(Occupant Classification System Module)																									V								
BT-50(RANGER)	4.0 Gasoline	4x4(4x4 Control Module)																																	
BT-50(RANGER)	4.0 Gasoline	RCM(Restraint Control Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BT-50(RANGER)	4.0 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																	
BT-50(RANGER)	4.0 Gasoline	TCM(Transmission Control Module)																																	
CX-3	1.5L S5	SYSTEM SEARCH																																	
CX-3	1.5L S5	PCM(Powertrain Control Module)																		V								V	V	V	V	V	V	V
CX-3	1.5L S5	TCM(Transmission Control Module)																																	
CX-3	1.5L S5	4x4(4x4 Control Module)																																	
CX-3	1.5L S5	ABS(Anti-Lock Brake System)																																	
CX-3	1.5L S5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																	
CX-3	1.5L S5	EATC(Electronic Automatic Temperature Control)																																	
CX-3	1.5L S5	EPS(Electronic-Controlled Power Steering)																																	
CX-3	1.5L S5	ESU(Electric Supply Unit)																																	
CX-3	1.5L S5	IC(Instrument Cluster)																																	
CX-3	1.5L S5	RCM(Restraint Control Module)																																	
CX-3	1.5L S5	BSM(Blind Spot Monitoring)																																	
CX-3	1.5L S5	BCM(Body Control Module)																																	
CX-3	1.5L S5	CMU(Connectivity Master Unit)																																	
CX-3	1.5L S5	FSC(Forward Sensing Camera)																																	
CX-3	1.5L S5	SSU(Smart Start Unit)																																	
CX-3	1.5L S5	SCBS(Smart City Brake Support)																																	
CX-3	1.5L S5	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-3	2.0L PE	SYSTEM SEARCH																																	
CX-3	2.0L PE	PCM(Powertrain Control Module)																										V	V						
CX-3	2.0L PE	TCM(Transmission Control Module)																																	
CX-3	2.0L PE	4x4(4x4 Control Module)																																	
CX-3	2.0L PE	ABS(Anti-Lock Brake System)																																	
CX-3	2.0L PE	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																	
CX-3	2.0L PE	EATC(Electronic Automatic Temperature Control)																																	
CX-3	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
CX-3	2.0L PE	ESU(Electric Supply Unit)																																	
CX-3	2.0L PE	IC(Instrument Cluster)																																	
CX-3	2.0L PE	RCM(Restraint Control Module)																																	
CX-3	2.0L PE	BSM(Blind Spot Monitoring)																																	
CX-3	2.0L PE	BCM(Body Control Module)																																	
CX-3	2.0L PE	CMU(Connectivity Master Unit)																																	
CX-3	2.0L PE	FSC(Forward Sensing Camera)																																	
CX-3	2.0L PE	SSU(Smart Start Unit)																																	
CX-3	2.0L PE	SCBS(Smart City Brake Support)																																	
CX-3	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.0L PE	SYSTEM SEARCH																																	
CX-5	2.0L PE	PCM(Powertrain Control Module)																										V	V						
CX-5	2.0L PE	TCM(Transmission Control Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
CX-5	2.0L PE	4x4(4x4 Control Module)																																	
CX-5	2.0L PE	ABS(Anti-Lock Brake System)																																	
CX-5	2.0L PE	ACU(Audio Control Unit)																																	
CX-5	2.0L PE	EATC(Electronic Automatic Temperature Control)																																	
CX-5	2.0L PE	AM(Amplifier Module)																																	
CX-5	2.0L PE	AFS(Adaptive Front Lighting System)																																	
CX-5	2.0L PE	DSM(Drivers Seat Module)																																	
CX-5	2.0L PE	DCDC(DC to DC Converter Control Module)																																	
CX-5	2.0L PE	FSC(Forward Sensing Camera)																																	
CX-5	2.0L PE	SCBS(Smart City Brake Support)																																	
CX-5	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
CX-5	2.0L PE	IC(Instrument Cluster)																																	
CX-5	2.0L PE	RVM(Rear Vehicle Monitoring)																																	
CX-5	2.0L PE	RCM(Restraint Control Module)																																	
CX-5	2.0L PE	SSU(Smart Start Unit)																																	
CX-5	2.0L PE	BSM(Blind Spot Monitoring)																																	
CX-5	2.0L PE	F_BCM(Front Body Control Module)																																	
CX-5	2.0L PE	R_BCM(Rear Body Control Module)																																	
CX-5	2.2L SH	SYSTEM SEARCH																																	
CX-5	2.2L SH	PCM(Powertrain Control Module)																		V								V	V	V	V	V		
CX-5	2.2L SH	TCM(Transmission Control Module)																																	
CX-5	2.2L SH	4x4(4x4 Control Module)																																	
CX-5	2.2L SH	ABS(Anti-Lock Brake System)																																	
CX-5	2.2L SH	ACU(Audio Control Unit)																																	
CX-5	2.2L SH	CMU(Connectivity Master Unit)																																	
CX-5	2.2L SH	EATC(Electronic Automatic Temperature Control)																																	
CX-5	2.2L SH	AM(Amplifier Module)																																	
CX-5	2.2L SH	AFS(Adaptive Front Lighting System)																																	
CX-5	2.2L SH	DSM(Drivers Seat Module)																																	
CX-5	2.2L SH	DCDC(DC to DC Converter Control Module)																																	
CX-5	2.2L SH	FSC(Forward Sensing Camera)																																	
CX-5	2.2L SH	SCBS(Smart City Brake Support)																																	
CX-5	2.2L SH	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.2L SH	EPB(Electonic Parking Brake)																																	
CX-5	2.2L SH	EPS(Electronic-Controlled Power Steering)																																	
CX-5	2.2L SH	IC(Instrument Cluster)																																	
CX-5	2.2L SH	RVM(Rear Vehicle Monitoring)																																	
CX-5	2.2L SH	RCM(Restraint Control Module)																																	
CX-5	2.2L SH	SSU(Smart Start Unit)																																	
CX-5	2.2L SH	BSM(Blind Spot Monitoring)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
CX-5	2.2L SH	F_BCM(Front Body Control Module)																																	
CX-5	2.2L SH	R_BCM(Rear Body Control Module)																																	
CX-5	2.5L PY	SYSTEM SEARCH																																	
CX-5	2.5L PY	PCM(Powertrain Control Module)																										V	V						
CX-5	2.5L PY	TCM(Transmission Control Module)																																	
CX-5	2.5L PY	4x4(4x4 Control Module)																																	
CX-5	2.5L PY	ABS(Anti-Lock Brake System)																																	
CX-5	2.5L PY	AM(Amplifier Module)																																	
CX-5	2.5L PY	DSM(Drivers Seat Module)																																	
CX-5	2.5L PY	EATC(Electronic Automatic Temperature Control)																																	
CX-5	2.5L PY	EPB(Electonic Parking Brake)																																	
CX-5	2.5L PY	EPS(Electronic-Controlled Power Steering)																																	
CX-5	2.5L PY	IC(Instrument Cluster)																																	
CX-5	2.5L PY	RCM(Restraint Control Module)																																	
CX-5	2.5L PY	AFS(Adaptive Front Lighting System)																																	
CX-5	2.5L PY	FSC(Forward Sensing Camera)																																	
CX-5	2.5L PY	SSU(Smart Start Unit)																																	
CX-5	2.5L PY	BSM(Blind Spot Monitoring)-JAPAN																																	
CX-5	2.5L PY	BSML(Blind Spot Monitoring Left)																																	
CX-5	2.5L PY	BSMR(Blind Spot Monitoring Right)																																	
CX-5	2.5L PY	F_BCM(Front Body Control Module)																																	
CX-5	2.5L PY	R_BCM(Rear Body Control Module)																																	
CX-5	2.5L PY	SCBS(Smart City Brake Support)																																	
CX-5	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.5L PY	ACU(Audio Control Unit)																																	
CX-5	2.5L PY	CMU(Connectivity Master Unit)																																	
CX-7	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
CX-7	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)																																	
CX-7	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta														V	V	V																	
CX-7	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)									V																								
CX-7	2.2L R2_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
CX-7	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
CX-7	2.2L R2_T (Diesel)	GEM(Generic Electronic Module)																																	
CX-7	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																	
CX-7	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																																	
CX-7	2.2L R2_T (Diesel)	MID(Multi-Information Display)																																	
CX-7	2.2L R2_T (Diesel)	SCR CU(Selective Catalytic Reduction)																																	
CX-7	2.2L R2_T (Diesel)	RKE(Remote Keyless Entry)																																	
CX-7	2.2L R2_T (Diesel)	RVM(Rear Vehicle Monitoring)																																	
CX-7	2.2L R2_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																	
CX-7	2.3L L3_T	SYSTEM SEARCH																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
CX-7	2.3L L3_T	PCM(Powertrain Control Module)																																	
CX-7	2.3L L3_T	PATS(Passive anti theft system)-Beta														V	V	V																	
CX-7	2.3L L3_T	ABS(Anti-Lock Brake System)									V																								
CX-7	2.3L L3_T	EATC(Electronic Automatic Temperature Control)																																	
CX-7	2.3L L3_T	AM(Amplifier Module)																																	
CX-7	2.3L L3_T	GEM(Generic Electronic Module)																																	
CX-7	2.3L L3_T	IC(Instrument Cluster)																																	
CX-7	2.3L L3_T	RCM(Restraint Control Module)																																	
CX-7	2.3L L3_T	TCM(Transmission Control Module)																																	
CX-7	2.3L L3_T	ACU(Audio Control Unit)																																	
CX-7	2.3L L3_T	4*4(4*4 Control Module)																																	
CX-7	2.3L L3_T	MID(Multi-Information Display)																																	
CX-7	2.3L L3_T	RKE(Remote Keyless Entry)																																	
CX-7	2.3L L3_T	LCM(Lighting Control Module)																																	
CX-7	2.3L L3_T	RVM(Rear Vehicle Monitoring)																																	
CX-7	2.5L L5	SYSTEM SEARCH																																	
CX-7	2.5L L5	PCM(Powertrain Control Module)																																	
CX-7	2.5L L5	PATS(Passive anti theft system)-Beta														V	V	V																	
CX-7	2.5L L5	TCM(Transmission Control Module)																																	
CX-7	2.5L L5	ABS(Anti-Lock Brake System)									V																								
CX-7	2.5L L5	RCM(Restraint Control Module)																																	
CX-7	2.5L L5	GEM(Generic Electronic Module)																																	
CX-7	2.5L L5	IC(Instrument Cluster)																																	
CX-7	2.5L L5	MID(Multi-Information Display)-Beta Test																																	
CX-7	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	
CX-7	2.5L L5	ACU(Audio Control Unit)																																	
CX-7	2.5L L5	ICCM(Intelligent Cruise Control Module)																																	
CX-7	2.5L L5	RKE(Remote Keyless Entry)																																	
CX-7	2.5L L5	RVM(Rear Vehicle Monitoring)																																	
CX-7	2.5L L5	LCM(Lighting Control Module)																																	
CX-9	3.7L CA	SYSTEM SEARCH																																	
CX-9	3.7L CA	PCM(Powertrain Control Module)																																	
CX-9	3.7L CA	PATS(Passive anti theft system)-Beta														V	V	V																	
CX-9	3.7L CA	ABS(Anti-Lock Brake System)																																	
CX-9	3.7L CA	4WD(Four Wheel Drive)-Beta Test																																	
CX-9	3.7L CA	DSM(Drivers Seat Module)																																	
CX-9	3.7L CA	GEM(Generic Electronic Module)																																	
CX-9	3.7L CA	IC(Instrument Cluster) - Without Tire Pressure Monitor																																	
CX-9	3.7L CA	IC(Instrument Cluster) - With Tire Pressure Monitor-Beta Test																																	
CX-9	3.7L CA	LCM(Lighting Control Module)-Beta Test																																	
CX-9	3.7L CA	LTM(Liftgate/Trunk Module)-Beta Test																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
CX-9	3.7L CA	RCM(Restraint Control Module) - Except USA																																	
CX-9	3.7L CA	RCM(Restraint Control Module) - USA-Beta Test																																	
CX-9	3.7L CA	RKE(Remote Keyless Entry)-Beta Test																																	
CX-9	3.7L CA	TCM(Transmission Control Module)																																	
CX-9	3.7L CA	BSML(Blind Spot Monitoring Left)-Beta Test																																	
CX-9	3.7L CA	BSMR(Blind Spot Monitoring Right)-Beta Test																																	
CX-9	3.5L CY-Beta Test	SYSTEM SEARCH																																	
CX-9	3.5L CY-Beta Test	PCM(Powertrain Control Module)																																	
CX-9	3.5L CY-Beta Test	PATS(Passive anti theft system)-Beta														V	V	V																	
CX-9	3.5L CY-Beta Test	ABS(Anti-Lock Brake System)																																	
CX-9	3.5L CY-Beta Test	4WD(Four Wheel Drive)																																	
CX-9	3.5L CY-Beta Test	GEM(Generic Electronic Module)																																	
CX-9	3.5L CY-Beta Test	IC(Instrument Cluster) - Without Tire Pressure Monitor																																	
CX-9	3.5L CY-Beta Test	IC(Instrument Cluster) - With Tire Pressure Monitor																																	
CX-9	3.5L CY-Beta Test	LTM(Liftgate/Trunk Module)																																	
CX-9	3.5L CY-Beta Test	RCM(Restraint Control Module) - USA																																	
CX-9	3.5L CY-Beta Test	RKE(Remote Keyless Entry)																																	
CX-9	3.5L CY-Beta Test	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.3L ZJ	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	PATS(Passive anti theft system)-Beta														V	V	V																	
DEMIOVERISAMAZDA2	1.3L ZJ	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	RKE(Remote Keyless Entry)														V	V	V																	
DEMIOVERISAMAZDA2	1.3L P3	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.3L P3	PCM(Powertrain Control Module)																											V	V					
DEMIOVERISAMAZDA2	1.3L P3	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.3L P3	BCM(Body Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	EATC(Electronic Automatic Temperature Control)																																	
DEMIOVERISAMAZDA2	1.3L P3	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.3L P3	FSC(Forward Sensing Camera)																																	
DEMIOVERISAMAZDA2	1.3L P3	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.3L P3	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	SSU(Smart Start Unit)																																	
DEMIOVERISAMAZDA2	1.3L P3	SCBS(Smart City Brake Support)																																	
DEMIOVERISAMAZDA2	1.3L P3	ALM(Auto Leveling Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	BSM(Blind Spot Monitoring)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
DEMIOVERISAMAZDA2	1.3L P3	CMU(Connectivity Master Unit)																																	
DEMIOVERISAMAZDA2	1.3L P3	ESU(Electric Supply Unit)																																	
DEMIOVERISAMAZDA2	1.5L ZY	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L ZY	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.5L ZY	PATS(Passive anti theft system)-Beta														V	V	V																	
DEMIOVERISAMAZDA2	1.5L ZY	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.5L ZY	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.5L ZY	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.5L ZY	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
DEMIOVERISAMAZDA2	1.5L ZY	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.5L ZY	RKE(Remote Keyless Entry)	With SKE																																
DEMIOVERISAMAZDA2	1.5L ZY	RKE(Remote Keyless Entry)	Without SKE													V	V	V																	
DEMIOVERISAMAZDA2	1.5L ZY	VSM(Vehicle Security Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L P5	PCM(Powertrain Control Module)																											V	V					
DEMIOVERISAMAZDA2	1.5L P5	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.5L P5	EATC(Electronic Automatic Temperature Control)																																	
DEMIOVERISAMAZDA2	1.5L P5	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.5L P5	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.5L P5	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	BSM(Blind Spot Monitoring)																																	
DEMIOVERISAMAZDA2	1.5L P5	BCM(Body Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	FSC(Forward Sensing Camera)																																	
DEMIOVERISAMAZDA2	1.5L P5	SSU(Smart Start Unit)																																	
DEMIOVERISAMAZDA2	1.5L P5	SCBS(Smart City Brake Support)																																	
DEMIOVERISAMAZDA2	1.5L P5	ALM(Auto Leveling Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	CMU(Connectivity Master Unit)																																	
DEMIOVERISAMAZDA2	1.5L P5	ESU(Electric Supply Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L S5	PCM(Powertrain Control Module)																		V								V	V	V	V	V	V	V
DEMIOVERISAMAZDA2	1.5L S5	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	4x4(4x4 Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.5L S5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	EATC(Electronic Automatic Temperature Control)																																	
DEMIOVERISAMAZDA2	1.5L S5	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.5L S5	ESU(Electric Supply Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.5L S5	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	BSM(Blind Spot Monitoring)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
DEMIOVERISAMAZDA2	1.5L S5	BCM(Body Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	CMU(Connectivity Master Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	FSC(Forward Sensing Camera)																																	
DEMIOVERISAMAZDA2	1.5L S5	SSU(Smart Start Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	SCBS(Smart City Brake Support)																																	
DEMIOVERISAMAZDA2	1.5L S5	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	PATS(Passive anti theft system)-Beta														V	V	V																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RKE(Remote Keyless Entry)	With SKE																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RKE(Remote Keyless Entry)	Without SKE													V	V	V																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	VSM(Vehicle Security Module)																																	
AXELAMAZDA3	1.5L ZY	SYSTEM SEARCH																																	
AXELAMAZDA3	1.5L ZY	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	1.5L ZY	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	1.5L ZY	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	1.5L ZY	RCM(Restraint Control Module)																																	
AXELAMAZDA3	1.5L ZY	IC(Instrument Cluster)																																	
AXELAMAZDA3	1.5L ZY	GEM(Generic Electronic Module)																																	
AXELAMAZDA3	1.5L ZY	PATS(Passive anti theft system)-Beta														V	V	V																	
AXELAMAZDA3	1.6L Y6	SYSTEM SEARCH																																	
AXELAMAZDA3	1.6L Y6	PCM(Powertrain Control Module)				V	V	V																											
AXELAMAZDA3	1.6L Y6	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	1.6L Y6	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	1.6L Y6	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	1.6L Y6	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	1.6L Y6	FACM(Fuel Additive Control Module)																																	
AXELAMAZDA3	1.6L Y6	IC(Instrument Cluster)																																	
AXELAMAZDA3	1.6L Y6	RCM(Restraint Control Module)																																	
AXELAMAZDA3	1.6L Y6	RKE(Remote Keyless Entry)																																	
AXELAMAZDA3	1.6L Y6	BSML(Blind Spot Monitoring Left)																																	
AXELAMAZDA3	1.6L Y6	BSMR(Blind Spot Monitoring Right)																																	
AXELAMAZDA3	1.6L Y6	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	1.6L Y6	MID(Multi-Information Display)																																	
AXELAMAZDA3	1.6L Y6	ACU(Audio Control Unit)																																	
AXELAMAZDA3	1.6L Y6	PATS(Passive anti theft system)-Beta														V	V	V																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
AXELAMAZDA3	1.6L Z6	SYSTEM SEARCH																																	
AXELAMAZDA3	1.6L Z6	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	1.6L Z6	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	1.6L Z6	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	1.6L Z6	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	1.6L Z6	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	1.6L Z6	IC(Instrument Cluster)																																	
AXELAMAZDA3	1.6L Z6	GEM(Generic Electronic Module)																																	
AXELAMAZDA3	1.6L Z6	MID(Multi-Information Display)																																	
AXELAMAZDA3	1.6L Z6	RCM(Restraint Control Module)																																	
AXELAMAZDA3	1.6L Z6	ACU(Audio Control Unit)																																	
AXELAMAZDA3	1.6L Z6	PATS(Passive anti theft system)-Beta														V	V	V																	
AXELAMAZDA3	2.0L LF	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L LF	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.0L LF	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.0L LF	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.0L LF	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.0L LF	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.0L LF	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.0L LF	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.0L LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.0L LF	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.0L LF	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.0L LF	GEM(Generic Electronic Module)																																	
AXELAMAZDA3	2.0L LF	PATS(Passive anti theft system)-Beta														V	V	V																	
AXELAMAZDA3	2.0L PE	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L PE	PCM(Powertrain Control Module)																											V	V					
AXELAMAZDA3	2.0L PE	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.0L PE	4x4(4x4 Control Module)																																	
AXELAMAZDA3	2.0L PE	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.0L PE	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.0L PE	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.0L PE	AM(Amplifier Module)																																	
AXELAMAZDA3	2.0L PE	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.0L PE	DSM(Drivers Seat Module)																																	
AXELAMAZDA3	2.0L PE	DCDC(DC to DC Converter Control Module)																																	
AXELAMAZDA3	2.0L PE	FSC(Forward Sensing Camera)																																	
AXELAMAZDA3	2.0L PE	SCBS(Smart City Brake Support)																																	
AXELAMAZDA3	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
AXELAMAZDA3	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.0L PE	IC(Instrument Cluster)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
AXELAMAZDA3	2.0L PE	RVM(Rear Vehicle Monitoring)																																	
AXELAMAZDA3	2.0L PE	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.0L PE	SSU(Smart Start Unit)																																	
AXELAMAZDA3	2.0L PE	F_BCM(Front Body Control Module)																																	
AXELAMAZDA3	2.0L PE	R_BCM(Rear Body Control Module)																																	
AXELAMAZDA3	2.0L PE	CMU(Connectivity Master Unit)																																	
AXELAMAZDA3	2.3L L3_T	SYSTEM SEARCH																																	
AXELAMAZDA3	2.3L L3_T	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.3L L3_T	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.3L L3_T	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.3L L3_T	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.3L L3_T	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.3L L3_T	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.3L L3_T	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.3L L3_T	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.3L L3_T	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.3L L3_T	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.3L L3_T	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.3L L3_T	LCM(Lighting Control Module)																																	
AXELAMAZDA3	2.3L L3_T	RKE(Remote Keyless Entry)																																	
AXELAMAZDA3	2.3L L3_T	TPM(Tire Pressure Monitor)																																	
AXELAMAZDA3	2.3L L3_T	PATS(Passive anti theft system)-Beta														V	V	V																	
AXELAMAZDA3	2.5L L5	SYSTEM SEARCH																																	
AXELAMAZDA3	2.5L L5	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.5L L5	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.5L L5	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.5L L5	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.5L L5	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.5L L5	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.5L L5	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.5L L5	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.5L L5	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.5L L5	RKE(Remote Keyless Entry)																																	
AXELAMAZDA3	2.5L PY	SYSTEM SEARCH																																	
AXELAMAZDA3	2.5L PY	PCM(Powertrain Control Module)																											V	V					
AXELAMAZDA3	2.5L PY	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.5L PY	4x4(4x4 Control Module)																																	
AXELAMAZDA3	2.5L PY	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.5L PY	AM(Amplifier Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
AXELAMAZDA3	2.5L PY	DSM(Drivers Seat Module)																																	
AXELAMAZDA3	2.5L PY	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.5L PY	EPB(Electonic Parking Brake)																																	
AXELAMAZDA3	2.5L PY	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.5L PY	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.5L PY	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.5L PY	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.5L PY	FSC(Forward Sensing Camera)																																	
AXELAMAZDA3	2.5L PY	SSU(Smart Start Unit)																																	
AXELAMAZDA3	2.5L PY	F_BCM(Front Body Control Module)																																	
AXELAMAZDA3	2.5L PY	R_BCM(Rear Body Control Module)																																	
AXELAMAZDA3	2.5L PY	SCBS(Smart City Brake Support)																																	
AXELAMAZDA3	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
AXELAMAZDA3	2.5L PY	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.5L PY	CMU(Connectivity Master Unit)																																	
AXELAMAZDA3	2.5L PY	BSML(Blind Spot Monitoring Left)																																	
AXELAMAZDA3	2.5L PY	BSMR(Blind Spot Monitoring Right)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	PATS(Passive anti theft system)-Beta														V	V	V																	
AXELAMAZDA3	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta														V	V	V																	
AXELAMAZDA3	2.2L SH (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.2L SH (Diesel)	PCM(Powertrain Control Module)																		V								V	V	V	V	V		
AXELAMAZDA3	2.2L SH (Diesel)	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	4x4(4x4 Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.2L SH (Diesel)	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.2L SH (Diesel)	CMU(Connectivity Master Unit)																																	
AXELAMAZDA3	2.2L SH (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.2L SH (Diesel)	AM(Amplifier Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	AFS(Adaptive Front Lighting System)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
AXELAMAZDA3	2.2L SH (Diesel)	DSM(Drivers Seat Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	DCDC(DC to DC Converter Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	FSC(Forward Sensing Camera)																																	
AXELAMAZDA3	2.2L SH (Diesel)	SCBS(Smart City Brake Support)																																	
AXELAMAZDA3	2.2L SH (Diesel)	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
AXELAMAZDA3	2.2L SH (Diesel)	EPB(Electonic Parking Brake)																																	
AXELAMAZDA3	2.2L SH (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.2L SH (Diesel)	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.2L SH (Diesel)	RVM(Rear Vehicle Monitoring)																																	
AXELAMAZDA3	2.2L SH (Diesel)	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	SSU(Smart Start Unit)																																	
AXELAMAZDA3	2.2L SH (Diesel)	F_BCM(Front Body Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	R_BCM(Rear Body Control Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	SYSTEM SEARCH																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	PCM(Powertrain Control Module)				V	V	V																											
PREMACYMAZDA5	1.6L Y6 (BETA)	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	EPS(Electronic-Controlled Power Steering)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	IC(Instrument Cluster)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	LPSDM(Left Power Sliding Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	RKE(Remote Keyless Entry)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	RPSDM(Right Power Sliding Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	ACU(Audio Control Unit)																																	
PREMACYMAZDA5	1.8L (BETA)	2005	SYSTEM SEARCH																																
PREMACYMAZDA5	1.8L (BETA)	2005	PCM(Powertrain Control Module)-MT																																
PREMACYMAZDA5	1.8L (BETA)	2005	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	1.8L (BETA)	2005	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	1.8L (BETA)	2005	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	1.8L (BETA)	2005	GEM(Generic Electronic Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	RCM(Restraint Control Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	IC(Instrument Cluster)																																
PREMACYMAZDA5	1.8L (BETA)	2005	LPSDM(Left Power Sliding Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	RPSDM(Right Power Sliding Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	1.8L (BETA)	2005	PATS(Passive anti theft system)-Beta													V	V	V																	
PREMACYMAZDA5	2.0L LF	2005	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2005	PCM(Powertrain Control Module)	ALL																															
PREMACYMAZDA5	2.0L LF	2005	PCM(Powertrain Control Module)	AT																															
PREMACYMAZDA5	2.0L LF	2005	ABS(Anti-Lock Brake System)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
PREMACYMAZDA5	2.0L LF	2005	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.0L LF	2005	GEM(Generic Electronic Module)																																
PREMACYMAZDA5	2.0L LF	2005	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.0L LF	2005	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L LF	2005	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L LF	2005	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L LF	2005	PATS(Passive anti theft system)-Beta													V	V	V																	
PREMACYMAZDA5	2.0L LF	2007	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2007	PCM(Powertrain Control Module)																																
PREMACYMAZDA5	2.0L LF	2007	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	2.0L LF	2007	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.0L LF	2007	GEM(Generic Electronic Module)																																
PREMACYMAZDA5	2.0L LF	2007	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.0L LF	2007	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L LF	2007	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L LF	2007	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L LF	2007	PATS(Passive anti theft system)-Beta													V	V	V																	
PREMACYMAZDA5	2.0L LF	2010~	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2010~	PCM(Powertrain Control Module)																																
PREMACYMAZDA5	2.0L LF	2010~	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	2.0L LF	2010~	BCM/GEM(Body Control Module/Generic Electronic Module)																																
PREMACYMAZDA5	2.0L LF	2010~	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L LF	2010~	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.0L LF	2010~	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L LF	2010~	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L LF	2010~	LPSDM(Left Power Sliding Module)																																
PREMACYMAZDA5	2.0L LF	2010~	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.0L LF	2010~	RPSDM(Right Power Sliding Module)																																
PREMACYMAZDA5	2.0L LF	2010~	TCM(Transmission Control Module)																																
PREMACYMAZDA5	2.0L RF_T (Diesel)	SYSTEM SEARCH																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	PCM(Powertrain Control Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	TCM(Transmission Control Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	GEM(Generic Electronic Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	IC(Instrument Cluster)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	RKE(Remote Keyless Entry)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	PATS(Passive anti theft system)-Beta														V	V	V																	
PREMACYMAZDA5	2.3L L3	SYSTEM SEARCH																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
PREMACYMAZDA5	2.3L L3	PCM(Powertrain Control Module)																																	
PREMACYMAZDA5	2.3L L3	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	2.3L L3	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	2.3L L3	EPS(Electronic-Controlled Power Steering)																																	
PREMACYMAZDA5	2.3L L3	GEM(Generic Electronic Module)																																	
PREMACYMAZDA5	2.3L L3	IC(Instrument Cluster)																																	
PREMACYMAZDA5	2.3L L3	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	2.3L L3	TPM(Tire Pressure Monitor)																																	
PREMACYMAZDA5	2.5L L5	SYSTEM SEARCH																																	
PREMACYMAZDA5	2.5L L5	PCM(Powertrain Control Module)																																	
PREMACYMAZDA5	2.5L L5	TCM(Transmission Control Module)																																	
PREMACYMAZDA5	2.5L L5	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	2.5L L5	EPS(Electronic-Controlled Power Steering)																																	
PREMACYMAZDA5	2.5L L5	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	2.5L L5	IC(Instrument Cluster)																																	
PREMACYMAZDA5	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
PREMACYMAZDA5	2.5L L5	LPSDM(Left Power Sliding Module)																																	
PREMACYMAZDA5	2.5L L5	RPSDM(Right Power Sliding Module)																																	
PREMACYMAZDA5	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	2.5L L5	AFS(Adaptive Front Lighting System)																																	
PREMACYMAZDA5	2.5L L5	PATS(Passive anti theft system)-Beta														V	V	V																	
ATENZAMAZDA6	1.8L L8	SYSTEM SEARCH																																	
ATENZAMAZDA6	1.8L L8	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	1.8L L8	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	1.8L L8	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	1.8L L8	GEM(Generic Electronic Module)																																	
ATENZAMAZDA6	1.8L L8	IC(Instrument Cluster)																																	
ATENZAMAZDA6	1.8L L8	LHID(Left High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	1.8L L8	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	1.8L L8	RHID(Right High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	1.8L L8	RKE(Remote Keyless Entry)																																	
ATENZAMAZDA6	1.8L L8	PATS(Passive anti theft system)-Beta														V	V	V																	
ATENZAMAZDA6	2.0L PE	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.0L PE	PCM(Powertrain Control Module)																											V	V					
ATENZAMAZDA6	2.0L PE	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.0L PE	4x4(4x4 Control Module)																																	
ATENZAMAZDA6	2.0L PE	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.0L PE	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.0L PE	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.0L PE	EPB(Electonic Parking Brake)																																	
ATENZAMAZDA6	2.0L PE	AM(Amplifier Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
ATENZAMAZDA6	2.0L PE	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.0L PE	DSM(Drivers Seat Module)																																	
ATENZAMAZDA6	2.0L PE	DCDC(DC to DC Converter Control Module)																																	
ATENZAMAZDA6	2.0L PE	FSC(Forward Sensing Camera)																																	
ATENZAMAZDA6	2.0L PE	SCBS(Smart City Brake Support)																																	
ATENZAMAZDA6	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
ATENZAMAZDA6	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.0L PE	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.0L PE	RVM(Rear Vehicle Monitoring)																																	
ATENZAMAZDA6	2.0L PE	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.0L PE	SSU(Smart Start Unit)																																	
ATENZAMAZDA6	2.0L PE	F_BCM(Front Body Control Module)																																	
ATENZAMAZDA6	2.0L PE	R_BCM(Rear Body Control Module)																																	
ATENZAMAZDA6	2.0L PE	CMU(Connectivity Master Unit)																																	
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	PATS(Passive anti theft system)-Beta													V	V	V																	
ATENZAMAZDA6	2.0L LF	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.0L LF	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.0L LF	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.0L LF	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.0L LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
ATENZAMAZDA6	2.0L LF	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.0L LF	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.0L LF	GEM(Generic Electronic Module)																																	
ATENZAMAZDA6	2.0L LF	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.0L LF	LCM(Lighting Control Module)																																	
ATENZAMAZDA6	2.0L LF	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.0L LF	RHID(Right High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.0L LF	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.0L LF	LHID(Left High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.0L LF	RKE(Remote Keyless Entry)																																	
ATENZAMAZDA6	2.0L LF	PATS(Passive anti theft system)-Beta														V	V	V																	
ATENZAMAZDA6	2.3L L3	2.3L	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3L	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	ABS(Anti-Lock Brake System)							V																									
ATENZAMAZDA6	2.3L L3	2.3L	IC(Instrument Cluster)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
ATENZAMAZDA6	2.3L L3	2.3L	GEM(Generic Electronic Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	RHID(Right High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.3L L3	2.3L	LHID(Left High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.3L L3	2.3L	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	PATS(Passive anti theft system)-Beta													V	V	V																	
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	PATS(Passive anti theft system)-Beta													V	V	V																	
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	PATS(Passive anti theft system)-Beta													V	V	V																	
ATENZAMAZDA6	2.3L L3_T	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.3L L3_T	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.3L L3_T	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.3L L3_T	ABS(Anti-Lock Brake System)								V																									
ATENZAMAZDA6	2.3L L3_T	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.3L L3_T	LHID(Left High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.3L L3_T	RHID(Right High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.3L L3_T	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.3L L3_T	PATS(Passive anti theft system)-Beta														V	V	V																	
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	PATS(Passive anti theft system)-Beta													V	V	V																	
ATENZAMAZDA6	2.5L L5	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.5L L5	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.5L L5	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.5L L5	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.5L L5	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.5L L5	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.5L L5	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
ATENZAMAZDA6	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
ATENZAMAZDA6	2.5L L5	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.5L L5	LCM(Lighting Control Module)																																	
ATENZAMAZDA6	2.5L L5	PATS(Passive anti theft system)-Beta														V	V	V																	
ATENZAMAZDA6	2.5L PY	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.5L PY	PCM(Powertrain Control Module)																										V	V						
ATENZAMAZDA6	2.5L PY	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.5L PY	4x4(4x4 Control Module)																																	
ATENZAMAZDA6	2.5L PY	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.5L PY	AM(Amplifier Module)																																	
ATENZAMAZDA6	2.5L PY	BSML(Blind Spot Monitoring Left)																																	
ATENZAMAZDA6	2.5L PY	BSMR(Blind Spot Monitoring Right)																																	
ATENZAMAZDA6	2.5L PY	DSM(Drivers Seat Module)																																	
ATENZAMAZDA6	2.5L PY	DCDC(DC to DC Converter Control Module)																																	
ATENZAMAZDA6	2.5L PY	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.5L PY	EPB(Electonic Parking Brake)																																	
ATENZAMAZDA6	2.5L PY	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.5L PY	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.5L PY	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.5L PY	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.5L PY	FSC(Forward Sensing Camera)																																	
ATENZAMAZDA6	2.5L PY	SSU(Smart Start Unit)																																	
ATENZAMAZDA6	2.5L PY	F_BCM(Front Body Control Module)																																	
ATENZAMAZDA6	2.5L PY	R_BCM(Rear Body Control Module)																																	
ATENZAMAZDA6	2.5L PY	SCBS(Smart City Brake Support)																																	
ATENZAMAZDA6	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
ATENZAMAZDA6	2.5L PY	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.5L PY	CMU(Connectivity Master Unit)																																	
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	PCM(Powertrain Control Module)																	V															
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	FFH(Fuel Fired Coolant Heating Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	LHID(Left High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	RHID(Right High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	PCM(Powertrain Control Module)																													V			
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	ACU(Audio Control Unit)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	BCM/GEM(Body Control Module/Generic Electronic Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	GEM(Generic Electronic Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	EATC(Electronic Automatic Temperature Control)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	EPS(Electronic-Controlled Power Steering)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	FFH(Fuel Fired Coolant Heating Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	LCM(Lighting Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	RVM(Rear Vehicle Monitoring)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	PATS(Passive anti theft system)-Beta													V	V	V																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)																														V			
ATENZAMAZDA6	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	LCM(Lighting Control Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta														V	V	V																	
ATENZAMAZDA6	2.2L SH (Diesel)	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.2L SH (Diesel)	PCM(Powertrain Control Module)																		V								V	V	V	V	V			
ATENZAMAZDA6	2.2L SH (Diesel)	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	4x4(4x4 Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	AM(Amplifier Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	CMU(Connectivity Master Unit)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	DSM(Drivers Seat Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	DCDC(DC to DC Converter Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	FSC(Forward Sensing Camera)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SCBS(Smart City Brake Support)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	EPB(Electonic Parking Brake)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	RVM(Rear Vehicle Monitoring)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SSU(Smart Start Unit)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	F_BCM(Front Body Control Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
ATENZAMAZDA6	2.2L SH (Diesel)	R_BCM(Rear Body Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	BSM(Blind Spot Monitoring)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	PSM(Parking Sensor Module)																																	
MPVMAZDA8	2.3L L3	SYSTEM SEARCH																																	
MPVMAZDA8	2.3L L3	PCM(Powertrain Control Module)																																	
MPVMAZDA8	2.3L L3	ABS(Anti-Lock Brake System)																																	
MPVMAZDA8	2.3L L3_T	SYSTEM SEARCH																																	
MPVMAZDA8	2.3L L3_T	PCM(Powertrain Control Module)																																	
MPVMAZDA8	2.3L L3_T	ABS(Anti-Lock Brake System)									V																								
MPVMAZDA8	2.3L L3_T	AM(Amplifier Module)																																	
MPVMAZDA8	2.3L L3_T	GEM(Generic Electronic Module)																																	
MPVMAZDA8	2.3L L3_T	HCM(Headlamp Control Module)																																	
MPVMAZDA8	2.3L L3_T	ICCM(Intelligent Cruise Control Module)-Beta Test																																	
MPVMAZDA8	2.3L L3_T	IC(Instrument Cluster)																																	
MPVMAZDA8	2.3L L3_T	LTM(Liftgate/Trunk Module)-Beta Test																																	
MPVMAZDA8	2.3L L3_T	RCM(Restraint Control Module)																																	
MPVMAZDA8	2.3L L3_T	RKE(Remote Keyless Entry)																																	
MPVMAZDA8	2.3L L3_T	TCM(Transmission Control Module)																																	
MPVMAZDA8	2.3L L3_T	LCM(Lighting Control Module)-Beta Test																																	
MPVMAZDA8	2.3L L3_T	4x4(4x4 Control Module)																																	
MPVMAZDA8	2.3L L3_T	LPSDM(Left Power Sliding Door Module)																																	
MPVMAZDA8	2.3L L3_T	RPSDM(Right Power Sliding Door Module)																																	
ROADSTERMX-5	North America/General specs	2.0L LF	SYSTEM SEARCH																																
ROADSTERMX-5	North America/General specs	2.0L LF	PCM(Powertrain Control Module)	2006~																															
ROADSTERMX-5	North America/General specs	2.0L LF	PCM(Powertrain Control Module)	2008~																															
ROADSTERMX-5	North America/General specs	2.0L LF	ABS(Anti-Lock Brake System)								V																								
ROADSTERMX-5	North America/General specs	2.0L LF	IC(Instrument Cluster)																																
ROADSTERMX-5	North America/General specs	2.0L LF	RCM(Restraint Control Module)																																
ROADSTERMX-5	North America/General specs	2.0L LF	RHT(Retractable Hard Top)																																
ROADSTERMX-5	North America/General specs	2.0L LF	RKE(Remote Keyless Entry)																																
ROADSTERMX-5	North America/General specs	2.0L LF	TCM(Transmission Control Module)																																
ROADSTERMX-5	North America/General specs	2.0L LF	PATS(Passive anti theft system)-Beta													V	V	V																	
ROADSTERMX-5	North America/General specs	2.0L LF	DHS(Deployable Hood System)																																
ROADSTERMX-5	North America/General specs	1.5L P5	SYSTEM SEARCH																																
ROADSTERMX-5	North America/General specs	1.5L P5	PCM(Powertrain Control Module)																									V	V						
ROADSTERMX-5	North America/General specs	1.5L P5	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	North America/General specs	1.5L P5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	AM(Amplifier Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	DCDC(DC to DC Converter Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	EATC(Electronic Automatic Temperature Control)																																
ROADSTERMX-5	North America/General specs	1.5L P5	EPS(Electronic-Controlled Power Steering)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
ROADSTERMX-5	North America/General specs	1.5L P5	EVP(Electronical VACUUM PUMP)																																
ROADSTERMX-5	North America/General specs	1.5L P5	IC(Instrument Cluster)																																
ROADSTERMX-5	North America/General specs	1.5L P5	RCM(Restraint Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	TCM(Transmission Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	BSM(Blind Spot Monitoring)																																
ROADSTERMX-5	North America/General specs	1.5L P5	BCM(Body Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	FSC(Forward Sensing Camera)																																
ROADSTERMX-5	North America/General specs	1.5L P5	SSU(Smart Start Unit)																																
ROADSTERMX-5	North America/General specs	1.5L P5	CMU(Connectivity Master Unit)																																
ROADSTERMX-5	North America/General specs	1.5L P5	ESU(Electric Supply Unit)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	PCM(Powertrain Control Module)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	ABS(Anti-Lock Brake System)								V																								
ROADSTERMX-5	Europe/General Specs	2.0L LF	IC(Instrument Cluster)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	RCM(Restraint Control Module)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	RHT(Retractable Hard Top)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	RKE(Remote Keyless Entry)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	TCM(Transmission Control Module)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	PATS(Passive anti theft system)-Beta													V	V	V																	
ROADSTERMX-5	Europe/General Specs	2.0L LF	DHS(Deployable Hood System)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	PCM(Powertrain Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	ABS(Anti-Lock Brake System)								V																								
ROADSTERMX-5	Europe/General Specs	1.8L L8	IC(Instrument Cluster)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	RCM(Restraint Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	RHT(Retractable Hard Top)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	RKE(Remote Keyless Entry)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	TCM(Transmission Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	PATS(Passive anti theft system)-Beta													V	V	V																	
ROADSTERMX-5	Europe/General Specs	1.5L P5	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	PCM(Powertrain Control Module)																										V	V					
ROADSTERMX-5	Europe/General Specs	1.5L P5	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	AM(Amplifier Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	DCDC(DC to DC Converter Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	EATC(Electronic Automatic Temperature Control)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	EPS(Electronic-Controlled Power Steering)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	EVP(Electronical VACUUM PUMP)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	IC(Instrument Cluster)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	RCM(Restraint Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	TCM(Transmission Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
ROADSTERMX-5	Europe/General Specs	1.5L P5	BSM(Blind Spot Monitoring)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	BCM(Body Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	FSC(Forward Sensing Camera)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	SSU(Smart Start Unit)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	CMU(Connectivity Master Unit)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	ESU(Electric Supply Unit)																																
RX-8	North America Spec	13B	SYSTEM SEARCH																																
RX-8	North America Spec	13B	PCM(Powertrain Control Module)																																
RX-8	North America Spec	13B	PATS(Passive anti theft system)-Beta													V	V	V																	
RX-8	North America Spec	13B	ABS(Anti-Lock Brake System)																																
RX-8	North America Spec	13B	EPS(Electronic-Controlled Power Steering)																																
RX-8	North America Spec	13B	IC(Instrument Cluster)																																
RX-8	North America Spec	13B	RCM(Restraint Control Module)																																
RX-8	North America Spec	13B	RKE(Remote Keyless Entry)																																
RX-8	North America Spec	13B	TCM(Transmission Control Module)																																
RX-8	North America Spec	13B	TPM(Tire Pressure Monitor)																																
RX-8	North America Spec	13B	LCM(Lighting Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	SYSTEM SEARCH																																
RX-8	North America Spec	13B-MSP High-Power	PCM(Powertrain Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	PATS(Passive anti theft system)-Beta													V	V	V																	
RX-8	North America Spec	13B-MSP High-Power	ABS(Anti-Lock Brake System)																																
RX-8	North America Spec	13B-MSP High-Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	North America Spec	13B-MSP High-Power	IC(Instrument Cluster)																																
RX-8	North America Spec	13B-MSP High-Power	RCM(Restraint Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	RKE(Remote Keyless Entry)																																
RX-8	North America Spec	13B-MSP High-Power	TCM(Transmission Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	TPM(Tire Pressure Monitor)																																
RX-8	North America Spec	13B-MSP Standard-Power	SYSTEM SEARCH																																
RX-8	North America Spec	13B-MSP Standard-Power	PCM(Powertrain Control Module)																																
RX-8	North America Spec	13B-MSP Standard-Power	PATS(Passive anti theft system)-Beta													V	V	V																	
RX-8	North America Spec	13B-MSP Standard-Power	ABS(Anti-Lock Brake System)																																
RX-8	North America Spec	13B-MSP Standard-Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	North America Spec	13B-MSP Standard-Power	IC(Instrument Cluster)																																
RX-8	North America Spec	13B-MSP Standard-Power	RCM(Restraint Control Module)																																
RX-8	North America Spec	13B-MSP Standard-Power	RKE(Remote Keyless Entry)																																
RX-8	North America Spec	13B-MSP Standard-Power	TCM(Transmission Control Module)																																
RX-8	North America Spec	13B-MSP Standard-Power	TPM(Tire Pressure Monitor)																																
RX-8	General	13B	SYSTEM SEARCH																																
RX-8	General	13B	PCM(Powertrain Control Module)																																
RX-8	General	13B	PATS(Passive anti theft system)-Beta													V	V	V																	
RX-8	General	13B	ABS(Anti-Lock Brake System)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
RX-8	General	13B	EPS(Electronic-Controlled Power Steering)																																
RX-8	General	13B	IC(Instrument Cluster)																																
RX-8	General	13B	RCM(Restraint Control Module)																																
RX-8	General	13B	RKE(Remote Keyless Entry)																																
RX-8	General	13B	TCM(Transmission Control Module)																																
RX-8	General	13B MSP High Power	SYSTEM SEARCH																																
RX-8	General	13B MSP High Power	PCM(Powertrain Control Module)																																
RX-8	General	13B MSP High Power	PATS(Passive anti theft system)-Beta													V	V	V																	
RX-8	General	13B MSP High Power	ABS(Anti-Lock Brake System)																																
RX-8	General	13B MSP High Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	General	13B MSP High Power	IC(Instrument Cluster)																																
RX-8	General	13B MSP High Power	RCM(Restraint Control Module)																																
RX-8	General	13B MSP High Power	RKE(Remote Keyless Entry)																																
RX-8	General	13B MSP High Power	TCM(Transmission Control Module)																																
RX-8	General	13B MSP Standard Power	SYSTEM SEARCH																																
RX-8	General	13B MSP Standard Power	PCM(Powertrain Control Module)																																
RX-8	General	13B MSP Standard Power	PATS(Passive anti theft system)-Beta													V	V	V																	
RX-8	General	13B MSP Standard Power	ABS(Anti-Lock Brake System)																																
RX-8	General	13B MSP Standard Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	General	13B MSP Standard Power	IC(Instrument Cluster)																																
RX-8	General	13B MSP Standard Power	RCM(Restraint Control Module)																																
RX-8	General	13B MSP Standard Power	RKE(Remote Keyless Entry)																																
RX-8	General	13B MSP Standard Power	TCM(Transmission Control Module)																																
ESCAPETRIBUTE	Up to 2004	SYSTEM SEARCH																																	
ESCAPETRIBUTE	Up to 2004	PCM(PowerTrain Control Module)																																	
ESCAPETRIBUTE	Up to 2004	Immobilizer																																	
ESCAPETRIBUTE	Up to 2004	ABS(Anti-Lock Brake System)																			V														
ESCAPETRIBUTE	Up to 2004	RCM(Restraint Control Module)																			V														
ESCAPETRIBUTE	Up to 2004	GEM(Generic Electronic Module)																			V														
ESCAPETRIBUTE	From 2004	SYSTEM SEARCH																																	
ESCAPETRIBUTE	From 2004	PCM(PowerTrain Control Module)																																	
ESCAPETRIBUTE	From 2004	PATS(Passive anti theft system)																																	
ESCAPETRIBUTE	From 2004	ABS(Anti-Lock Brake System)																																	
ESCAPETRIBUTE	From 2004	RCM(Restraint Control Module)																																	
ESCAPETRIBUTE	From 2004	IC(Instrument Cluster)																																	
ESCAPETRIBUTE	From 2004	GEM(Generic Electronic Module)																																	
General(ALL Model)	16PIN CONNECTOR	SYSTEM SEARCH																																	
General(ALL Model)	16PIN CONNECTOR	PCM(PowerTrain Control Module)																																	
General(ALL Model)	16PIN CONNECTOR	PATS(Passive anti theft system)-Beta														V	V	V																	
General(ALL Model)	16PIN CONNECTOR	TCM(Transmission Control Module)																																	
General(ALL Model)	16PIN CONNECTOR	ABS(Anti-Lock Brake System)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
General(ALL Model)	16PIN CONNECTOR	RCM(Restraint Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	SYSTEM SEARCH																																	
General(ALL Model)	17PIN CONNECTOR	PCM(PowerTrain Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	TCM(Transmission Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	ABS(Anti-Lock Brake System)																																	
General(ALL Model)	17PIN CONNECTOR	RCM(Restraint Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	PCM(PowerTrain Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	TCM(Transmission Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	RCM(Restraint Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ABS(Anti-Lock Brake System)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ACCM(Air Conditioning Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	4WS(4 Wheel Steering)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ICCM(Intelligent Cruise Control Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RKE(Remote Keyless Entry)(WithSKE)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RKE(Remote Keyless Entry)(WIthout SKE)													V	V	V																	
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	VSM(Vehicle Security Module)																																
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	ASM																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	AT																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	PowerShift																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 (Low Power without DPF)	ASM																														

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 (Low Power without DPF)	ALL																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 + DPF (High Power with DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 3(High Power without DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 4(Low Power without DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 4 + DPF (High Power with DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 3(High Power without DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	FACM(Fuel Additive Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	1.6 Z6	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	GEM(Generic Electronic Module)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	ASM																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	AT																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	PowerShift																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	RCM(Restraint Control Module)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	FFH(Fuel Fired Coolant Heating Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	ASM																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	AT																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	PowerShift																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA GASOLINE ENGINE	PCM(Powertrain Control Module)																																	
BETA-ETC	MAZDA DIESEL ENGINE	PCM(Powertrain Control Module)																														V			
BETA-ETC	MAZDA 2 ENGINE	PCM(Powertrain Control Module)																																	
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	ABS(Anti-Lock Brake System)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	RCM(Restraint Control Module)																																
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	SYSTEM SEARCH																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	PCM(Powertrain Control Module)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	ABS(Anti-Lock Brake System)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	EPS(Electronic-Controlled Power Steering)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	IC(Instrument Cluster)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	4x4(4x4 Control Module)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	RCM(Restraint Control Module)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	RKE(Remote Keyless Entry)																																	
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	SYSTEM SEARCH																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	PCM(Powertrain Control Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	ABS(Anti-Lock Brake System)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	IC(Instrument Cluster)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	RCM(Restraint Control Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	RKE(Remote Keyless Entry)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	VSM(Vehicle Security Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	TCM(Transmission Control Module)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	EPS(Electronic-Controlled Power Steering)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	GEM(Generic Electronic Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	RCM(Restraint Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	RKE(Remote Keyless Entry)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	RKE(Remote Keyless Entry)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	TCM(Transmission Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	RCM(Restraint Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	MID(Multi-Information Display)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	RCM(Restraint Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	MID(Multi-Information Display)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	EATC(Electronic Automatic Temperature Control)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	ABS(Anti-Lock Brake System)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	RKE(Remote Keyless Entry)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	TCM(Transmission Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	SYSTEM SEARCH																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	PCM(Powertrain Control Module)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	IC(Instrument Cluster)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 3 (North America/General)	SYSTEM SEARCH																																	
BETA-ETC	MAZDA 3 (North America/General)	PCM(Powertrain Control Module)																																	
BETA-ETC	MAZDA 3 (North America/General)	ABS(Anti-Lock Brake System)																																	
BETA-ETC	MAZDA 3 (North America/General)	IC(Instrument Cluster)																																	
BETA-ETC	MAZDA 3 (North America/General)	TPM(Tire Pressure Monitor)																																	
BETA-ETC	MAZDA 3 (China/General)	1.6L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	RKE(Remote Keyless Entry)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	SYSTEM SEARCH																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	PCM(Powertrain Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	ABS(Anti-Lock Brake System)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	IC(Instrument Cluster)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	GEM(Generic Electronic Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RCM(Restraint Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	LPSDM(Left Power Sliding Door Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RPSDM(Right Power Sliding Door Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	TCM(Transmission Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RKE(Remote Keyless Entry)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	PCM(Powertrain Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	ABS(Anti-Lock Brake System)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	IC(Instrument Cluster)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	GEM(Generic Electronic Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RCM(Restraint Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	LPSDM(Left Power Sliding Door Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RPSDM(Right Power Sliding Door Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	TCM(Transmission Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	TPM(Tire Pressure Monitor)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	PCM(Powertrain Control Module)	ALL																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	LHID(Left High Intensity Discharge Lamp)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	PCM(Powertrain Control Module)	ALL																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	GEM(Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	LHID(Left High Intensity Discharge Lamp)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RHID(Right High Intensity Discharge Lamp)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	TCM(Transmission Control Module)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	SYSTEM SEARCH																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	PCM(Powertrain Control Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	ABS(Anti-Lock Brake System)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	GEM(Generic Electronic Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	IC(Instrument Cluster)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	LHID(Left High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RHID(Right High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RCM(Restraint Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RKE(Remote Keyless Entry)													V	V																		
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	TCM(Transmission Control Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	SYSTEM SEARCH																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	PCM(Powertrain Control Module)	ALL																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	PCM(Powertrain Control Module)	MT																												V			
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	GEM(Generic Electronic Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	LHID(Left High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RHID(Right High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	IC(Instrument Cluster)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RCM(Restraint Control Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RKE(Remote Keyless Entry)													V	V																		
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	IC(Instrument Cluster)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	PCM(Powertrain Control Module)																													V			
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	FFH(Fuel Fired Coolant Heating Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	PCM(Powertrain Control Module)-ALL																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	TPM(Tire Pressure Monitor)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	TPM(Tire Pressure Monitor)																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	FFH(Fuel Fired Coolant Heating Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	RCM(Restraint Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	GEM(Generic Electronic Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	HCM(Headlamp Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	ICCM(Intelligent Cruise Control Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	IC(Instrument Cluster)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	LTM(Liftgate/Trunk Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	RCM(Restraint Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	RKE(Remote Keyless Entry)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	ABS(Anti-Lock Brake System)								V																								
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	GEM(Generic Electronic Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	HCM(Headlamp Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	ICCM(Intelligent Cruise Control Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	IC(Instrument Cluster)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LTM(Liftgate/Trunk Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RCM(Restraint Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RKE(Remote Keyless Entry)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LCM(Lighting Control Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	4x4(4x4 Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LPSDM(Left Power Sliding Door Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RPSDM(Right Power Sliding Door Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset the Mass Air Flow Sensor Learned Values	Reset the Fuel Injector Learned Values	Reset the Turbocharger Learned Values	Stop-Start Activation	ABS Service Bleed	Steering Angle Sensor	Lateral Acceleration Sensor/Longitudinal Acceleration Sensor	ACM Module Installation	TBM SIM RAV_ID	Reset TBM Password	Ignition key code erase and program	Program additional Ignition key	Parameter reset	MAF Correction	PCM Reset	ON-Demand Self test	ActuationTest	Clear Transmission Adaptive Tables	Stop Use of Transmission Adaptive	Halt Transmission Adaptive Learning	Resume Transmission Adaptive Learning	Passenger System Reset	IVD Initialization Sequence	Engine Oil Maintenance-Change Setting	Engine Oil Maintenance-Remaining Oil Life	Injector amount correction learning	MAF Reset	O2 Sensor reset	Sediment Reset	Exhaust Shutter Valve initialization
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	SYSTEM SEARCH																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	PCM(Powertrain Control Module)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	ABS(Anti-Lock Brake System)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	IC(Instrument Cluster)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	TCM(Transmission Control Module)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	SYSTEM SEARCH																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	2005~																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	~2005																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	TCM(Transmission Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	SYSTEM SEARCH																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	PCM(Powertrain Control Module)																	V															
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	ABS(Anti-Lock Brake System)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	RCM(Restraint Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	TCM(Transmission Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	SYSTEM SEARCH																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	PCM(Powertrain Control Module)																	V															
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	ABS(Anti-Lock Brake System)																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	TCM(Transmission Control Module)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	PCM(Powertrain Control Module)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	ABS(Anti-Lock Brake System)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	GEM(Generic Electronic Module)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	IC(Instrument Cluster)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	RCM(Restraint Control Module)																																
BETA-ETC	TITAN DASH	2.0L RF_T	SYSTEM SEARCH																																
BETA-ETC	TITAN DASH	2.0L RF_T	PCM(Powertrain Control Module)																																
BETA-ETC	TITAN DASH	2.0L RF_T	TCM(Transmission Control Module)																																
BETA-ETC	PATS(Passive anti theft system)															V	V	V																	
BETA-ETC	Vehicle Log Capture																																		

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
Incode Calculator	Incode Calculator	~2010.05																																	
Service Manual	Reset the Oil Change Indicator(G-scan Support)																																		
Service Manual	Oil Light Reset / Service Light Reset(Manual)																																		
Service Manual	Throttle Body Learning																																		
BIANTE	2.0L LF	SYSTEM SEARCH																																	
BIANTE	2.0L LF	PCM(Powertrain Control Module)																																	
BIANTE	2.0L LF	ABS(Anti-Lock Brake System)																																	
BIANTE	2.0L LF	EATC(Electronic Automatic Temperature Control)																																	
BIANTE	2.0L LF	EPS(Electronic-Controlled Power Steering)																																	
BIANTE	2.0L LF	GEM(Generic Electronic Module)																																	
BIANTE	2.0L LF	IC(Instrument Cluster)																																	
BIANTE	2.0L LF	LPSDM(Left Power Sliding Door Module)																																	
BIANTE	2.0L LF	RCM(Restraint Control Module)																																	
BIANTE	2.0L LF	RKE(Remote Keyless Entry)																																	
BIANTE	2.0L LF	RPSDM(Right Power Sliding Door Module)																																	
BIANTE	2.0L LF	TCM(Transmission Control Module)																																	
BIANTE	2.3L L3	SYSTEM SEARCH																																	
BIANTE	2.3L L3	PCM(Powertrain Control Module)																																	
BIANTE	2.3L L3	ABS(Anti-Lock Brake System)																																	
BIANTE	2.3L L3	EATC(Electronic Automatic Temperature Control)																																	
BIANTE	2.3L L3	EPS(Electronic-Controlled Power Steering)																																	
BIANTE	2.3L L3	GEM(Generic Electronic Module)																																	
BIANTE	2.3L L3	IC(Instrument Cluster)																																	
BIANTE	2.3L L3	LPSDM(Left Power Sliding Door Module)																																	
BIANTE	2.3L L3	RCM(Restraint Control Module)																																	
BIANTE	2.3L L3	RKE(Remote Keyless Entry)																																	
BIANTE	2.3L L3	RPSDM(Right Power Sliding Door Module)																																	
BIANTE	2.3L L3	TCM(Transmission Control Module)																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	SYSTEM SEARCH																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	2005~																																
BONGOBRAWNYSPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	~2005																																
BONGOBRAWNYSPECTRON	2.0L RF_T	ABS(Anti-Lock Brake System)																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.2 Diesel	SYSTEM SEARCH																																	
BT-50(RANGER)	2.2 Diesel	PCM(PowerTrain Control Module)																																	
BT-50(RANGER)	2.2 Diesel	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	2.2 Diesel	ACM(Audio Control Module)																																	
BT-50(RANGER)	2.2 Diesel	BCMii(Body Control Module)																																	
BT-50(RANGER)	2.2 Diesel	DDM(Drivers Door Module)																																	
BT-50(RANGER)	2.2 Diesel	FCDIM(Front Control/Display Interface Module)																																	
BT-50(RANGER)	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BT-50(RANGER)	2.2 Diesel	IPC(Instrument Panel Control Module)																																	
BT-50(RANGER)	2.2 Diesel	PAM(Parking Aid Module)																																	
BT-50(RANGER)	2.2 Diesel	PDM(Passengers Door Module)																																	
BT-50(RANGER)	2.2 Diesel	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.2 Diesel	SRM(Speech Recognition Module)																																	
BT-50(RANGER)	2.2 Diesel	TBM(Tracking And Blocking Module)																																	
BT-50(RANGER)	2.2 Diesel	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.2 Diesel	TRM(Trailer Module)																																	
BT-50(RANGER)	2.2 Diesel	PATS(Passive anti theft system)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)																																	
BT-50(RANGER)	3.2 Diesel	SYSTEM SEARCH																																	
BT-50(RANGER)	3.2 Diesel	PCM(PowerTrain Control Module)																																	
BT-50(RANGER)	3.2 Diesel	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	3.2 Diesel	ACM(Audio Control Module)																																	
BT-50(RANGER)	3.2 Diesel	BCMii(Body Control Module)																																	
BT-50(RANGER)	3.2 Diesel	DDM(Drivers Door Module)																																	
BT-50(RANGER)	3.2 Diesel	FCDIM(Front Control/Display Interface Module)																																	
BT-50(RANGER)	3.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																	
BT-50(RANGER)	3.2 Diesel	IPC(Instrument Panel Control Module)																																	
BT-50(RANGER)	3.2 Diesel	PAM(Parking Aid Module)																																	
BT-50(RANGER)	3.2 Diesel	PDM(Passengers Door Module)																																	
BT-50(RANGER)	3.2 Diesel	RCM(Restraint Control Module)																																	
BT-50(RANGER)	3.2 Diesel	SRM(Speech Recognition Module)																																	
BT-50(RANGER)	3.2 Diesel	TBM(Tracking And Blocking Module)																																	
BT-50(RANGER)	3.2 Diesel	TCM(Transmission Control Module)																																	
BT-50(RANGER)	3.2 Diesel	TRM(Trailer Module)																																	
BT-50(RANGER)	3.2 Diesel	PATS(Passive anti theft system)																																	
BT-50(RANGER)	2.3 Gasoline	PCM(Powertrain Control Module)																																	
BT-50(RANGER)	2.3 Gasoline	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	2.3 Gasoline	GEM(Generic Electronic Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BT-50(RANGER)	2.3 Gasoline	IC(Instrument Cluster)																																	
BT-50(RANGER)	2.3 Gasoline	OCSM(Occupant Classification System Module)																																	
BT-50(RANGER)	2.3 Gasoline	4x4(4x4 Control Module)																																	
BT-50(RANGER)	2.3 Gasoline	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.3 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																	
BT-50(RANGER)	2.3 Gasoline	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	2.5 Gasoline	PCM(PowerTrain Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	2.5 Gasoline	ACM(Audio Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	BCMii(Body Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	DDM(Drivers Door Module)																																	
BT-50(RANGER)	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																																	
BT-50(RANGER)	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																																	
BT-50(RANGER)	2.5 Gasoline	IPC(Instrument Panel Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	PAM(Parking Aid Module)																																	
BT-50(RANGER)	2.5 Gasoline	PDM(Passengers Door Module)																																	
BT-50(RANGER)	2.5 Gasoline	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	SRM(Speech Recognition Module)																																	
BT-50(RANGER)	2.5 Gasoline	TBM(Tracking And Blocking Module)																																	
BT-50(RANGER)	2.5 Gasoline	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	TRM(Trailer Module)																																	
BT-50(RANGER)	2.5 Gasoline	PATS(Passive anti theft system)																																	
BT-50(RANGER)	3.0 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	3.0 Gasoline	PCM(Powertrain Control Module)																																	
BT-50(RANGER)	3.0 Gasoline	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	3.0 Gasoline	GEM(Generic Electronic Module)																																	
BT-50(RANGER)	3.0 Gasoline	IC(Instrument Cluster)																																	
BT-50(RANGER)	3.0 Gasoline	OCSM(Occupant Classification System Module)																																	
BT-50(RANGER)	3.0 Gasoline	4x4(4x4 Control Module)																																	
BT-50(RANGER)	3.0 Gasoline	RCM(Restraint Control Module)																																	
BT-50(RANGER)	3.0 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																	
BT-50(RANGER)	3.0 Gasoline	TCM(Transmission Control Module)																																	
BT-50(RANGER)	4.0 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	4.0 Gasoline	PCM(Powertrain Control Module)																																	
BT-50(RANGER)	4.0 Gasoline	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	4.0 Gasoline	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																	
BT-50(RANGER)	4.0 Gasoline	IC(Instrument Cluster)																																	
BT-50(RANGER)	4.0 Gasoline	OCSM(Occupant Classification System Module)																																	
BT-50(RANGER)	4.0 Gasoline	4x4(4x4 Control Module)																																	
BT-50(RANGER)	4.0 Gasoline	RCM(Restraint Control Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BT-50(RANGER)	4.0 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																	
BT-50(RANGER)	4.0 Gasoline	TCM(Transmission Control Module)																																	
CX-3	1.5L S5	SYSTEM SEARCH																																	
CX-3	1.5L S5	PCM(Powertrain Control Module)				V	V																												
CX-3	1.5L S5	TCM(Transmission Control Module)																																	
CX-3	1.5L S5	4x4(4x4 Control Module)						V																											
CX-3	1.5L S5	ABS(Anti-Lock Brake System)							V																										
CX-3	1.5L S5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)								V	V																								
CX-3	1.5L S5	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
CX-3	1.5L S5	EPS(Electronic-Controlled Power Steering)																																	
CX-3	1.5L S5	ESU(Electric Supply Unit)																																	
CX-3	1.5L S5	IC(Instrument Cluster)																																	
CX-3	1.5L S5	RCM(Restraint Control Module)																																	
CX-3	1.5L S5	BSM(Blind Spot Monitoring)																																	
CX-3	1.5L S5	BCM(Body Control Module)																																	
CX-3	1.5L S5	CMU(Connectivity Master Unit)																																	
CX-3	1.5L S5	FSC(Forward Sensing Camera)																V																	
CX-3	1.5L S5	SSU(Smart Start Unit)																																	
CX-3	1.5L S5	SCBS(Smart City Brake Support)																																	
CX-3	1.5L S5	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-3	2.0L PE	SYSTEM SEARCH																																	
CX-3	2.0L PE	PCM(Powertrain Control Module)																																	
CX-3	2.0L PE	TCM(Transmission Control Module)																																	
CX-3	2.0L PE	4x4(4x4 Control Module)						V																											
CX-3	2.0L PE	ABS(Anti-Lock Brake System)							V																										
CX-3	2.0L PE	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)								V	V																								
CX-3	2.0L PE	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
CX-3	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
CX-3	2.0L PE	ESU(Electric Supply Unit)																																	
CX-3	2.0L PE	IC(Instrument Cluster)																																	
CX-3	2.0L PE	RCM(Restraint Control Module)																																	
CX-3	2.0L PE	BSM(Blind Spot Monitoring)																																	
CX-3	2.0L PE	BCM(Body Control Module)																																	
CX-3	2.0L PE	CMU(Connectivity Master Unit)																																	
CX-3	2.0L PE	FSC(Forward Sensing Camera)																V																	
CX-3	2.0L PE	SSU(Smart Start Unit)																																	
CX-3	2.0L PE	SCBS(Smart City Brake Support)																																	
CX-3	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.0L PE	SYSTEM SEARCH																																	
CX-5	2.0L PE	PCM(Powertrain Control Module)																																	
CX-5	2.0L PE	TCM(Transmission Control Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
CX-5	2.0L PE	4x4(4x4 Control Module)						V																											
CX-5	2.0L PE	ABS(Anti-Lock Brake System)							V																										
CX-5	2.0L PE	ACU(Audio Control Unit)																																	
CX-5	2.0L PE	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
CX-5	2.0L PE	AM(Amplifier Module)																																	
CX-5	2.0L PE	AFS(Adaptive Front Lighting System)								V	V																								
CX-5	2.0L PE	DSM(Drivers Seat Module)																																	
CX-5	2.0L PE	DCDC(DC to DC Converter Control Module)																																	
CX-5	2.0L PE	FSC(Forward Sensing Camera)																V																	
CX-5	2.0L PE	SCBS(Smart City Brake Support)																																	
CX-5	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
CX-5	2.0L PE	IC(Instrument Cluster)																																	
CX-5	2.0L PE	RVM(Rear Vehicle Monitoring)																																	
CX-5	2.0L PE	RCM(Restraint Control Module)																																	
CX-5	2.0L PE	SSU(Smart Start Unit)																																	
CX-5	2.0L PE	BSM(Blind Spot Monitoring)																																	
CX-5	2.0L PE	F_BCM(Front Body Control Module)																																	
CX-5	2.0L PE	R_BCM(Rear Body Control Module)																																	
CX-5	2.2L SH	SYSTEM SEARCH																																	
CX-5	2.2L SH	PCM(Powertrain Control Module)				V	V												V																
CX-5	2.2L SH	TCM(Transmission Control Module)																																	
CX-5	2.2L SH	4x4(4x4 Control Module)						V																											
CX-5	2.2L SH	ABS(Anti-Lock Brake System)							V																										
CX-5	2.2L SH	ACU(Audio Control Unit)																																	
CX-5	2.2L SH	CMU(Connectivity Master Unit)																																	
CX-5	2.2L SH	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
CX-5	2.2L SH	AM(Amplifier Module)																																	
CX-5	2.2L SH	AFS(Adaptive Front Lighting System)								V	V																								
CX-5	2.2L SH	DSM(Drivers Seat Module)																																	
CX-5	2.2L SH	DCDC(DC to DC Converter Control Module)																																	
CX-5	2.2L SH	FSC(Forward Sensing Camera)																V																	
CX-5	2.2L SH	SCBS(Smart City Brake Support)																																	
CX-5	2.2L SH	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.2L SH	EPB(Electonic Parking Brake)																																	
CX-5	2.2L SH	EPS(Electronic-Controlled Power Steering)																																	
CX-5	2.2L SH	IC(Instrument Cluster)																																	
CX-5	2.2L SH	RVM(Rear Vehicle Monitoring)																																	
CX-5	2.2L SH	RCM(Restraint Control Module)																																	
CX-5	2.2L SH	SSU(Smart Start Unit)																																	
CX-5	2.2L SH	BSM(Blind Spot Monitoring)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
CX-5	2.2L SH	F_BCM(Front Body Control Module)																																	
CX-5	2.2L SH	R_BCM(Rear Body Control Module)																																	
CX-5	2.5L PY	SYSTEM SEARCH																																	
CX-5	2.5L PY	PCM(Powertrain Control Module)																																	
CX-5	2.5L PY	TCM(Transmission Control Module)																																	
CX-5	2.5L PY	4x4(4x4 Control Module)						V																											
CX-5	2.5L PY	ABS(Anti-Lock Brake System)							V																										
CX-5	2.5L PY	AM(Amplifier Module)																																	
CX-5	2.5L PY	DSM(Drivers Seat Module)																																	
CX-5	2.5L PY	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
CX-5	2.5L PY	EPB(Electonic Parking Brake)																																	
CX-5	2.5L PY	EPS(Electronic-Controlled Power Steering)																																	
CX-5	2.5L PY	IC(Instrument Cluster)																																	
CX-5	2.5L PY	RCM(Restraint Control Module)																																	
CX-5	2.5L PY	AFS(Adaptive Front Lighting System)								V	V																								
CX-5	2.5L PY	FSC(Forward Sensing Camera)																V																	
CX-5	2.5L PY	SSU(Smart Start Unit)																																	
CX-5	2.5L PY	BSM(Blind Spot Monitoring)-JAPAN																																	
CX-5	2.5L PY	BSML(Blind Spot Monitoring Left)																																	
CX-5	2.5L PY	BSMR(Blind Spot Monitoring Right)																																	
CX-5	2.5L PY	F_BCM(Front Body Control Module)																																	
CX-5	2.5L PY	R_BCM(Rear Body Control Module)																																	
CX-5	2.5L PY	SCBS(Smart City Brake Support)																																	
CX-5	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.5L PY	ACU(Audio Control Unit)																																	
CX-5	2.5L PY	CMU(Connectivity Master Unit)																																	
CX-7	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
CX-7	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)																		V															
CX-7	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
CX-7	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																	
CX-7	2.2L R2_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
CX-7	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
CX-7	2.2L R2_T (Diesel)	GEM(Generic Electronic Module)																																	
CX-7	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																	
CX-7	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																												V					
CX-7	2.2L R2_T (Diesel)	MID(Multi-Information Display)																																	
CX-7	2.2L R2_T (Diesel)	SCR CU(Selective Catalytic Reduction)																													V	V	V		
CX-7	2.2L R2_T (Diesel)	RKE(Remote Keyless Entry)																																	
CX-7	2.2L R2_T (Diesel)	RVM(Rear Vehicle Monitoring)																																	
CX-7	2.2L R2_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																	
CX-7	2.3L L3_T	SYSTEM SEARCH																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
CX-7	2.3L L3_T	PCM(Powertrain Control Module)																																	
CX-7	2.3L L3_T	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
CX-7	2.3L L3_T	ABS(Anti-Lock Brake System)																																	
CX-7	2.3L L3_T	EATC(Electronic Automatic Temperature Control)																																	
CX-7	2.3L L3_T	AM(Amplifier Module)																																	
CX-7	2.3L L3_T	GEM(Generic Electronic Module)																																	
CX-7	2.3L L3_T	IC(Instrument Cluster)																																V	V
CX-7	2.3L L3_T	RCM(Restraint Control Module)																												V					
CX-7	2.3L L3_T	TCM(Transmission Control Module)																																	
CX-7	2.3L L3_T	ACU(Audio Control Unit)																																	
CX-7	2.3L L3_T	4*4(4*4 Control Module)																																	
CX-7	2.3L L3_T	MID(Multi-Information Display)																																	
CX-7	2.3L L3_T	RKE(Remote Keyless Entry)																																	
CX-7	2.3L L3_T	LCM(Lighting Control Module)																																	
CX-7	2.3L L3_T	RVM(Rear Vehicle Monitoring)																																	
CX-7	2.5L L5	SYSTEM SEARCH																																	
CX-7	2.5L L5	PCM(Powertrain Control Module)																																	
CX-7	2.5L L5	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
CX-7	2.5L L5	TCM(Transmission Control Module)																																	
CX-7	2.5L L5	ABS(Anti-Lock Brake System)																																	
CX-7	2.5L L5	RCM(Restraint Control Module)																												V					
CX-7	2.5L L5	GEM(Generic Electronic Module)																																	
CX-7	2.5L L5	IC(Instrument Cluster)																																	
CX-7	2.5L L5	MID(Multi-Information Display)-Beta Test																																	
CX-7	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	
CX-7	2.5L L5	ACU(Audio Control Unit)																																	
CX-7	2.5L L5	ICCM(Intelligent Cruise Control Module)																																	
CX-7	2.5L L5	RKE(Remote Keyless Entry)																																	
CX-7	2.5L L5	RVM(Rear Vehicle Monitoring)																																	
CX-7	2.5L L5	LCM(Lighting Control Module)																																	
CX-9	3.7L CA	SYSTEM SEARCH																																	
CX-9	3.7L CA	PCM(Powertrain Control Module)																																	
CX-9	3.7L CA	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
CX-9	3.7L CA	ABS(Anti-Lock Brake System)																																	
CX-9	3.7L CA	4WD(Four Wheel Drive)-Beta Test																																	
CX-9	3.7L CA	DSM(Drivers Seat Module)																																	
CX-9	3.7L CA	GEM(Generic Electronic Module)																																	
CX-9	3.7L CA	IC(Instrument Cluster) - Without Tire Pressure Monitor																																	
CX-9	3.7L CA	IC(Instrument Cluster) - With Tire Pressure Monitor-Beta Test																																	
CX-9	3.7L CA	LCM(Lighting Control Module)-Beta Test																																	
CX-9	3.7L CA	LTM(Liftgate/Trunk Module)-Beta Test																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
CX-9	3.7L CA	RCM(Restraint Control Module) - Except USA																																	
CX-9	3.7L CA	RCM(Restraint Control Module) - USA-Beta Test																																	
CX-9	3.7L CA	RKE(Remote Keyless Entry)-Beta Test																																	
CX-9	3.7L CA	TCM(Transmission Control Module)																																	
CX-9	3.7L CA	BSML(Blind Spot Monitoring Left)-Beta Test																																	
CX-9	3.7L CA	BSMR(Blind Spot Monitoring Right)-Beta Test																																	
CX-9	3.5L CY-Beta Test	SYSTEM SEARCH																																	
CX-9	3.5L CY-Beta Test	PCM(Powertrain Control Module)																																	
CX-9	3.5L CY-Beta Test	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
CX-9	3.5L CY-Beta Test	ABS(Anti-Lock Brake System)																																	
CX-9	3.5L CY-Beta Test	4WD(Four Wheel Drive)																																	
CX-9	3.5L CY-Beta Test	GEM(Generic Electronic Module)																																	
CX-9	3.5L CY-Beta Test	IC(Instrument Cluster) - Without Tire Pressure Monitor																																	
CX-9	3.5L CY-Beta Test	IC(Instrument Cluster) - With Tire Pressure Monitor																																	
CX-9	3.5L CY-Beta Test	LTM(Liftgate/Trunk Module)																																	
CX-9	3.5L CY-Beta Test	RCM(Restraint Control Module) - USA																																	
CX-9	3.5L CY-Beta Test	RKE(Remote Keyless Entry)																																	
CX-9	3.5L CY-Beta Test	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.3L ZJ	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
DEMIOVERISAMAZDA2	1.3L ZJ	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	RCM(Restraint Control Module)																												V					
DEMIOVERISAMAZDA2	1.3L ZJ	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	RKE(Remote Keyless Entry)																							V	V									
DEMIOVERISAMAZDA2	1.3L P3	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.3L P3	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.3L P3	BCM(Body Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	EATC(Electronic Automatic Temperature Control)																																	
DEMIOVERISAMAZDA2	1.3L P3	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.3L P3	FSC(Forward Sensing Camera)																V																	
DEMIOVERISAMAZDA2	1.3L P3	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.3L P3	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	SSU(Smart Start Unit)																																	
DEMIOVERISAMAZDA2	1.3L P3	SCBS(Smart City Brake Support)																																	
DEMIOVERISAMAZDA2	1.3L P3	ALM(Auto Leveling Module)								V	V																								
DEMIOVERISAMAZDA2	1.3L P3	BSM(Blind Spot Monitoring)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
DEMIOVERISAMAZDA2	1.3L P3	CMU(Connectivity Master Unit)																																	
DEMIOVERISAMAZDA2	1.3L P3	ESU(Electric Supply Unit)																																	
DEMIOVERISAMAZDA2	1.5L ZY	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L ZY	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.5L ZY	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
DEMIOVERISAMAZDA2	1.5L ZY	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.5L ZY	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.5L ZY	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.5L ZY	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
DEMIOVERISAMAZDA2	1.5L ZY	RCM(Restraint Control Module)																												V					
DEMIOVERISAMAZDA2	1.5L ZY	RKE(Remote Keyless Entry)	With SKE																																
DEMIOVERISAMAZDA2	1.5L ZY	RKE(Remote Keyless Entry)	Without SKE																					V	V										
DEMIOVERISAMAZDA2	1.5L ZY	VSM(Vehicle Security Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L P5	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	ABS(Anti-Lock Brake System)							V																										
DEMIOVERISAMAZDA2	1.5L P5	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
DEMIOVERISAMAZDA2	1.5L P5	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.5L P5	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.5L P5	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	BSM(Blind Spot Monitoring)																																	
DEMIOVERISAMAZDA2	1.5L P5	BCM(Body Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	FSC(Forward Sensing Camera)																V																	
DEMIOVERISAMAZDA2	1.5L P5	SSU(Smart Start Unit)																																	
DEMIOVERISAMAZDA2	1.5L P5	SCBS(Smart City Brake Support)																																	
DEMIOVERISAMAZDA2	1.5L P5	ALM(Auto Leveling Module)								V	V																								
DEMIOVERISAMAZDA2	1.5L P5	CMU(Connectivity Master Unit)																																	
DEMIOVERISAMAZDA2	1.5L P5	ESU(Electric Supply Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L S5	PCM(Powertrain Control Module)				V	V																												
DEMIOVERISAMAZDA2	1.5L S5	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	4x4(4x4 Control Module)						V																											
DEMIOVERISAMAZDA2	1.5L S5	ABS(Anti-Lock Brake System)							V																										
DEMIOVERISAMAZDA2	1.5L S5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)								V	V																								
DEMIOVERISAMAZDA2	1.5L S5	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
DEMIOVERISAMAZDA2	1.5L S5	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.5L S5	ESU(Electric Supply Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.5L S5	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	BSM(Blind Spot Monitoring)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
DEMIOVERISAMAZDA2	1.5L S5	BCM(Body Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	CMU(Connectivity Master Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	FSC(Forward Sensing Camera)																V																	
DEMIOVERISAMAZDA2	1.5L S5	SSU(Smart Start Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	SCBS(Smart City Brake Support)																																	
DEMIOVERISAMAZDA2	1.5L S5	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
DEMIOVERISAMAZDA2	1.6L Y6-Beta	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RCM(Restraint Control Module)																												V					
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RKE(Remote Keyless Entry)	With SKE																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RKE(Remote Keyless Entry)	Without SKE																					V	V										
DEMIOVERISAMAZDA2	1.6L Y6-Beta	VSM(Vehicle Security Module)																																	
AXELAMAZDA3	1.5L ZY	SYSTEM SEARCH																																	
AXELAMAZDA3	1.5L ZY	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	1.5L ZY	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	1.5L ZY	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	1.5L ZY	RCM(Restraint Control Module)																																	
AXELAMAZDA3	1.5L ZY	IC(Instrument Cluster)																																	
AXELAMAZDA3	1.5L ZY	GEM(Generic Electronic Module)																																	
AXELAMAZDA3	1.5L ZY	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
AXELAMAZDA3	1.6L Y6	SYSTEM SEARCH																																	
AXELAMAZDA3	1.6L Y6	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	1.6L Y6	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	1.6L Y6	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	1.6L Y6	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	1.6L Y6	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	1.6L Y6	FACM(Fuel Additive Control Module)																																	
AXELAMAZDA3	1.6L Y6	IC(Instrument Cluster)																																	
AXELAMAZDA3	1.6L Y6	RCM(Restraint Control Module)																																	
AXELAMAZDA3	1.6L Y6	RKE(Remote Keyless Entry)																																	
AXELAMAZDA3	1.6L Y6	BSML(Blind Spot Monitoring Left)																																	
AXELAMAZDA3	1.6L Y6	BSMR(Blind Spot Monitoring Right)																																	
AXELAMAZDA3	1.6L Y6	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	1.6L Y6	MID(Multi-Information Display)																																	
AXELAMAZDA3	1.6L Y6	ACU(Audio Control Unit)																																	
AXELAMAZDA3	1.6L Y6	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
AXELAMAZDA3	1.6L Z6	SYSTEM SEARCH																																	
AXELAMAZDA3	1.6L Z6	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	1.6L Z6	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	1.6L Z6	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	1.6L Z6	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	1.6L Z6	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	1.6L Z6	IC(Instrument Cluster)																																	
AXELAMAZDA3	1.6L Z6	GEM(Generic Electronic Module)																																	
AXELAMAZDA3	1.6L Z6	MID(Multi-Information Display)																																	
AXELAMAZDA3	1.6L Z6	RCM(Restraint Control Module)																																	
AXELAMAZDA3	1.6L Z6	ACU(Audio Control Unit)																																	
AXELAMAZDA3	1.6L Z6	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
AXELAMAZDA3	2.0L LF	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L LF	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.0L LF	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.0L LF	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.0L LF	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.0L LF	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.0L LF	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.0L LF	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.0L LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.0L LF	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.0L LF	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.0L LF	GEM(Generic Electronic Module)																																	
AXELAMAZDA3	2.0L LF	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
AXELAMAZDA3	2.0L PE	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L PE	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.0L PE	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.0L PE	4x4(4x4 Control Module)						V																											
AXELAMAZDA3	2.0L PE	ABS(Anti-Lock Brake System)							V																										
AXELAMAZDA3	2.0L PE	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.0L PE	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
AXELAMAZDA3	2.0L PE	AM(Amplifier Module)																																	
AXELAMAZDA3	2.0L PE	AFS(Adaptive Front Lighting System)								V	V																								
AXELAMAZDA3	2.0L PE	DSM(Drivers Seat Module)																																	
AXELAMAZDA3	2.0L PE	DCDC(DC to DC Converter Control Module)																																	
AXELAMAZDA3	2.0L PE	FSC(Forward Sensing Camera)																V																	
AXELAMAZDA3	2.0L PE	SCBS(Smart City Brake Support)																																	
AXELAMAZDA3	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
AXELAMAZDA3	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.0L PE	IC(Instrument Cluster)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
AXELAMAZDA3	2.0L PE	RVM(Rear Vehicle Monitoring)																																	
AXELAMAZDA3	2.0L PE	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.0L PE	SSU(Smart Start Unit)																																	
AXELAMAZDA3	2.0L PE	F_BCM(Front Body Control Module)																																	
AXELAMAZDA3	2.0L PE	R_BCM(Rear Body Control Module)																																	
AXELAMAZDA3	2.0L PE	CMU(Connectivity Master Unit)																																	
AXELAMAZDA3	2.3L L3_T	SYSTEM SEARCH																																	
AXELAMAZDA3	2.3L L3_T	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.3L L3_T	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.3L L3_T	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.3L L3_T	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.3L L3_T	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.3L L3_T	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.3L L3_T	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.3L L3_T	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.3L L3_T	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.3L L3_T	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.3L L3_T	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.3L L3_T	LCM(Lighting Control Module)																																	
AXELAMAZDA3	2.3L L3_T	RKE(Remote Keyless Entry)																																	
AXELAMAZDA3	2.3L L3_T	TPM(Tire Pressure Monitor)																																	
AXELAMAZDA3	2.3L L3_T	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
AXELAMAZDA3	2.5L L5	SYSTEM SEARCH																																	
AXELAMAZDA3	2.5L L5	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.5L L5	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.5L L5	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.5L L5	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.5L L5	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.5L L5	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.5L L5	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.5L L5	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.5L L5	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.5L L5	RKE(Remote Keyless Entry)																																	
AXELAMAZDA3	2.5L PY	SYSTEM SEARCH																																	
AXELAMAZDA3	2.5L PY	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.5L PY	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.5L PY	4x4(4x4 Control Module)						V																											
AXELAMAZDA3	2.5L PY	ABS(Anti-Lock Brake System)							V																										
AXELAMAZDA3	2.5L PY	AM(Amplifier Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
AXELAMAZDA3	2.5L PY	DSM(Drivers Seat Module)																																	
AXELAMAZDA3	2.5L PY	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
AXELAMAZDA3	2.5L PY	EPB(Electonic Parking Brake)																																	
AXELAMAZDA3	2.5L PY	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.5L PY	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.5L PY	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.5L PY	AFS(Adaptive Front Lighting System)								V	V																								
AXELAMAZDA3	2.5L PY	FSC(Forward Sensing Camera)																V																	
AXELAMAZDA3	2.5L PY	SSU(Smart Start Unit)																																	
AXELAMAZDA3	2.5L PY	F_BCM(Front Body Control Module)																																	
AXELAMAZDA3	2.5L PY	R_BCM(Rear Body Control Module)																																	
AXELAMAZDA3	2.5L PY	SCBS(Smart City Brake Support)																																	
AXELAMAZDA3	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
AXELAMAZDA3	2.5L PY	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.5L PY	CMU(Connectivity Master Unit)																																	
AXELAMAZDA3	2.5L PY	BSML(Blind Spot Monitoring Left)																																	
AXELAMAZDA3	2.5L PY	BSMR(Blind Spot Monitoring Right)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
AXELAMAZDA3	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)																		V															
AXELAMAZDA3	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
AXELAMAZDA3	2.2L SH (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.2L SH (Diesel)	PCM(Powertrain Control Module)				V	V												V																
AXELAMAZDA3	2.2L SH (Diesel)	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	4x4(4x4 Control Module)						V																											
AXELAMAZDA3	2.2L SH (Diesel)	ABS(Anti-Lock Brake System)							V																										
AXELAMAZDA3	2.2L SH (Diesel)	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.2L SH (Diesel)	CMU(Connectivity Master Unit)																																	
AXELAMAZDA3	2.2L SH (Diesel)	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
AXELAMAZDA3	2.2L SH (Diesel)	AM(Amplifier Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	AFS(Adaptive Front Lighting System)								V	V																								

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
AXELAMAZDA3	2.2L SH (Diesel)	DSM(Drivers Seat Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	DCDC(DC to DC Converter Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	FSC(Forward Sensing Camera)																V																	
AXELAMAZDA3	2.2L SH (Diesel)	SCBS(Smart City Brake Support)																																	
AXELAMAZDA3	2.2L SH (Diesel)	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
AXELAMAZDA3	2.2L SH (Diesel)	EPB(Electonic Parking Brake)																																	
AXELAMAZDA3	2.2L SH (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.2L SH (Diesel)	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.2L SH (Diesel)	RVM(Rear Vehicle Monitoring)																																	
AXELAMAZDA3	2.2L SH (Diesel)	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	SSU(Smart Start Unit)																																	
AXELAMAZDA3	2.2L SH (Diesel)	F_BCM(Front Body Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	R_BCM(Rear Body Control Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	SYSTEM SEARCH																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	PCM(Powertrain Control Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	EPS(Electronic-Controlled Power Steering)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	IC(Instrument Cluster)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	LPSDM(Left Power Sliding Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	RKE(Remote Keyless Entry)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	RPSDM(Right Power Sliding Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	ACU(Audio Control Unit)																																	
PREMACYMAZDA5	1.8L (BETA)	2005	SYSTEM SEARCH																																
PREMACYMAZDA5	1.8L (BETA)	2005	PCM(Powertrain Control Module)-MT																																
PREMACYMAZDA5	1.8L (BETA)	2005	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	1.8L (BETA)	2005	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	1.8L (BETA)	2005	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	1.8L (BETA)	2005	GEM(Generic Electronic Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	RCM(Restraint Control Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	IC(Instrument Cluster)																																
PREMACYMAZDA5	1.8L (BETA)	2005	LPSDM(Left Power Sliding Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	RPSDM(Right Power Sliding Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	1.8L (BETA)	2005	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
PREMACYMAZDA5	2.0L LF	2005	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2005	PCM(Powertrain Control Module)	ALL																															
PREMACYMAZDA5	2.0L LF	2005	PCM(Powertrain Control Module)	AT																															
PREMACYMAZDA5	2.0L LF	2005	ABS(Anti-Lock Brake System)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
PREMACYMAZDA5	2.0L LF	2005	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.0L LF	2005	GEM(Generic Electronic Module)																																
PREMACYMAZDA5	2.0L LF	2005	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.0L LF	2005	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L LF	2005	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L LF	2005	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L LF	2005	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
PREMACYMAZDA5	2.0L LF	2007	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2007	PCM(Powertrain Control Module)																																
PREMACYMAZDA5	2.0L LF	2007	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	2.0L LF	2007	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.0L LF	2007	GEM(Generic Electronic Module)																																
PREMACYMAZDA5	2.0L LF	2007	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.0L LF	2007	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L LF	2007	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L LF	2007	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L LF	2007	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
PREMACYMAZDA5	2.0L LF	2010~	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2010~	PCM(Powertrain Control Module)																																
PREMACYMAZDA5	2.0L LF	2010~	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	2.0L LF	2010~	BCM/GEM(Body Control Module/Generic Electronic Module)																																
PREMACYMAZDA5	2.0L LF	2010~	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L LF	2010~	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.0L LF	2010~	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L LF	2010~	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L LF	2010~	LPSDM(Left Power Sliding Module)																																
PREMACYMAZDA5	2.0L LF	2010~	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.0L LF	2010~	RPSDM(Right Power Sliding Module)																																
PREMACYMAZDA5	2.0L LF	2010~	TCM(Transmission Control Module)																																
PREMACYMAZDA5	2.0L RF_T (Diesel)	SYSTEM SEARCH																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	PCM(Powertrain Control Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	TCM(Transmission Control Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	GEM(Generic Electronic Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	IC(Instrument Cluster)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	RKE(Remote Keyless Entry)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
PREMACYMAZDA5	2.3L L3	SYSTEM SEARCH																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
PREMACYMAZDA5	2.3L L3	PCM(Powertrain Control Module)																																	
PREMACYMAZDA5	2.3L L3	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	2.3L L3	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	2.3L L3	EPS(Electronic-Controlled Power Steering)																																	
PREMACYMAZDA5	2.3L L3	GEM(Generic Electronic Module)																																	
PREMACYMAZDA5	2.3L L3	IC(Instrument Cluster)																																	
PREMACYMAZDA5	2.3L L3	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	2.3L L3	TPM(Tire Pressure Monitor)																																	
PREMACYMAZDA5	2.5L L5	SYSTEM SEARCH																																	
PREMACYMAZDA5	2.5L L5	PCM(Powertrain Control Module)																																	
PREMACYMAZDA5	2.5L L5	TCM(Transmission Control Module)																																	
PREMACYMAZDA5	2.5L L5	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	2.5L L5	EPS(Electronic-Controlled Power Steering)																																	
PREMACYMAZDA5	2.5L L5	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	2.5L L5	IC(Instrument Cluster)																																	
PREMACYMAZDA5	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
PREMACYMAZDA5	2.5L L5	LPSDM(Left Power Sliding Module)																																	
PREMACYMAZDA5	2.5L L5	RPSDM(Right Power Sliding Module)																																	
PREMACYMAZDA5	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	2.5L L5	AFS(Adaptive Front Lighting System)																																	
PREMACYMAZDA5	2.5L L5	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
ATENZAMAZDA6	1.8L L8	SYSTEM SEARCH																																	
ATENZAMAZDA6	1.8L L8	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	1.8L L8	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	1.8L L8	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	1.8L L8	GEM(Generic Electronic Module)																																	
ATENZAMAZDA6	1.8L L8	IC(Instrument Cluster)																																	
ATENZAMAZDA6	1.8L L8	LHID(Left High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	1.8L L8	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	1.8L L8	RHID(Right High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	1.8L L8	RKE(Remote Keyless Entry)																																	
ATENZAMAZDA6	1.8L L8	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
ATENZAMAZDA6	2.0L PE	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.0L PE	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.0L PE	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.0L PE	4x4(4x4 Control Module)						V																											
ATENZAMAZDA6	2.0L PE	ABS(Anti-Lock Brake System)							V																										
ATENZAMAZDA6	2.0L PE	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.0L PE	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
ATENZAMAZDA6	2.0L PE	EPB(Electonic Parking Brake)																																	
ATENZAMAZDA6	2.0L PE	AM(Amplifier Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
ATENZAMAZDA6	2.0L PE	AFS(Adaptive Front Lighting System)								V	V																								
ATENZAMAZDA6	2.0L PE	DSM(Drivers Seat Module)																																	
ATENZAMAZDA6	2.0L PE	DCDC(DC to DC Converter Control Module)																																	
ATENZAMAZDA6	2.0L PE	FSC(Forward Sensing Camera)																V																	
ATENZAMAZDA6	2.0L PE	SCBS(Smart City Brake Support)																																	
ATENZAMAZDA6	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
ATENZAMAZDA6	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.0L PE	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.0L PE	RVM(Rear Vehicle Monitoring)																																	
ATENZAMAZDA6	2.0L PE	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.0L PE	SSU(Smart Start Unit)																																	
ATENZAMAZDA6	2.0L PE	F_BCM(Front Body Control Module)																																	
ATENZAMAZDA6	2.0L PE	R_BCM(Rear Body Control Module)																																	
ATENZAMAZDA6	2.0L PE	CMU(Connectivity Master Unit)																																	
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
ATENZAMAZDA6	2.0L LF	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.0L LF	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.0L LF	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.0L LF	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.0L LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
ATENZAMAZDA6	2.0L LF	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.0L LF	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.0L LF	GEM(Generic Electronic Module)																																	
ATENZAMAZDA6	2.0L LF	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.0L LF	LCM(Lighting Control Module)																																	
ATENZAMAZDA6	2.0L LF	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.0L LF	RHID(Right High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.0L LF	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.0L LF	LHID(Left High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.0L LF	RKE(Remote Keyless Entry)																																	
ATENZAMAZDA6	2.0L LF	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
ATENZAMAZDA6	2.3L L3	2.3L	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3L	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3	2.3L	IC(Instrument Cluster)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
ATENZAMAZDA6	2.3L L3	2.3L	GEM(Generic Electronic Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	RHID(Right High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.3L L3	2.3L	LHID(Left High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.3L L3	2.3L	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
ATENZAMAZDA6	2.3L L3_T	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.3L L3_T	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.3L L3_T	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.3L L3_T	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.3L L3_T	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.3L L3_T	LHID(Left High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.3L L3_T	RHID(Right High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.3L L3_T	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.3L L3_T	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
ATENZAMAZDA6	2.5L L5	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.5L L5	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.5L L5	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.5L L5	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.5L L5	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.5L L5	RCM(Restraint Control Module)																												V					
ATENZAMAZDA6	2.5L L5	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
ATENZAMAZDA6	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
ATENZAMAZDA6	2.5L L5	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.5L L5	LCM(Lighting Control Module)																																	
ATENZAMAZDA6	2.5L L5	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
ATENZAMAZDA6	2.5L PY	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.5L PY	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.5L PY	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.5L PY	4x4(4x4 Control Module)						V																											
ATENZAMAZDA6	2.5L PY	ABS(Anti-Lock Brake System)							V																										
ATENZAMAZDA6	2.5L PY	AM(Amplifier Module)																																	
ATENZAMAZDA6	2.5L PY	BSML(Blind Spot Monitoring Left)																																	
ATENZAMAZDA6	2.5L PY	BSMR(Blind Spot Monitoring Right)																																	
ATENZAMAZDA6	2.5L PY	DSM(Drivers Seat Module)																																	
ATENZAMAZDA6	2.5L PY	DCDC(DC to DC Converter Control Module)																																	
ATENZAMAZDA6	2.5L PY	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
ATENZAMAZDA6	2.5L PY	EPB(Electonic Parking Brake)																																	
ATENZAMAZDA6	2.5L PY	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.5L PY	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.5L PY	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.5L PY	AFS(Adaptive Front Lighting System)								V	V																								
ATENZAMAZDA6	2.5L PY	FSC(Forward Sensing Camera)																V																	
ATENZAMAZDA6	2.5L PY	SSU(Smart Start Unit)																																	
ATENZAMAZDA6	2.5L PY	F_BCM(Front Body Control Module)																																	
ATENZAMAZDA6	2.5L PY	R_BCM(Rear Body Control Module)																																	
ATENZAMAZDA6	2.5L PY	SCBS(Smart City Brake Support)																																	
ATENZAMAZDA6	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
ATENZAMAZDA6	2.5L PY	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.5L PY	CMU(Connectivity Master Unit)																																	
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	FFH(Fuel Fired Coolant Heating Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	LHID(Left High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	RHID(Right High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	ACU(Audio Control Unit)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	BCM/GEM(Body Control Module/Generic Electronic Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	GEM(Generic Electronic Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	EATC(Electronic Automatic Temperature Control)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	EPS(Electronic-Controlled Power Steering)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	FFH(Fuel Fired Coolant Heating Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	RCM(Restraint Control Module)																											V					
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	LCM(Lighting Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	RVM(Rear Vehicle Monitoring)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
ATENZAMAZDA6	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																												V					
ATENZAMAZDA6	2.2L R2_T (Diesel)	LCM(Lighting Control Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
ATENZAMAZDA6	2.2L SH (Diesel)	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.2L SH (Diesel)	PCM(Powertrain Control Module)				V	V												V																
ATENZAMAZDA6	2.2L SH (Diesel)	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	4x4(4x4 Control Module)						V																											
ATENZAMAZDA6	2.2L SH (Diesel)	ABS(Anti-Lock Brake System)							V																										
ATENZAMAZDA6	2.2L SH (Diesel)	AM(Amplifier Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	CMU(Connectivity Master Unit)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	EATC(Electronic Automatic Temperature Control)										V	V	V	V	V	V																		
ATENZAMAZDA6	2.2L SH (Diesel)	AFS(Adaptive Front Lighting System)								V	V																								
ATENZAMAZDA6	2.2L SH (Diesel)	DSM(Drivers Seat Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	DCDC(DC to DC Converter Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	FSC(Forward Sensing Camera)																V																	
ATENZAMAZDA6	2.2L SH (Diesel)	SCBS(Smart City Brake Support)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	EPB(Electonic Parking Brake)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	RVM(Rear Vehicle Monitoring)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SSU(Smart Start Unit)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	F_BCM(Front Body Control Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
ATENZAMAZDA6	2.2L SH (Diesel)	R_BCM(Rear Body Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	BSM(Blind Spot Monitoring)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	PSM(Parking Sensor Module)																																	
MPVMAZDA8	2.3L L3	SYSTEM SEARCH																																	
MPVMAZDA8	2.3L L3	PCM(Powertrain Control Module)																																	
MPVMAZDA8	2.3L L3	ABS(Anti-Lock Brake System)																																	
MPVMAZDA8	2.3L L3_T	SYSTEM SEARCH																																	
MPVMAZDA8	2.3L L3_T	PCM(Powertrain Control Module)																																	
MPVMAZDA8	2.3L L3_T	ABS(Anti-Lock Brake System)																																	
MPVMAZDA8	2.3L L3_T	AM(Amplifier Module)																																	
MPVMAZDA8	2.3L L3_T	GEM(Generic Electronic Module)																																	
MPVMAZDA8	2.3L L3_T	HCM(Headlamp Control Module)																																	
MPVMAZDA8	2.3L L3_T	ICCM(Intelligent Cruise Control Module)-Beta Test																																	
MPVMAZDA8	2.3L L3_T	IC(Instrument Cluster)																																	
MPVMAZDA8	2.3L L3_T	LTM(Liftgate/Trunk Module)-Beta Test																																	
MPVMAZDA8	2.3L L3_T	RCM(Restraint Control Module)																																	
MPVMAZDA8	2.3L L3_T	RKE(Remote Keyless Entry)																																	
MPVMAZDA8	2.3L L3_T	TCM(Transmission Control Module)																																	
MPVMAZDA8	2.3L L3_T	LCM(Lighting Control Module)-Beta Test																																	
MPVMAZDA8	2.3L L3_T	4x4(4x4 Control Module)																																	
MPVMAZDA8	2.3L L3_T	LPSDM(Left Power Sliding Door Module)																																	
MPVMAZDA8	2.3L L3_T	RPSDM(Right Power Sliding Door Module)																																	
ROADSTERMX-5	North America/General specs	2.0L LF	SYSTEM SEARCH																																
ROADSTERMX-5	North America/General specs	2.0L LF	PCM(Powertrain Control Module)	2006~																															
ROADSTERMX-5	North America/General specs	2.0L LF	PCM(Powertrain Control Module)	2008~																															
ROADSTERMX-5	North America/General specs	2.0L LF	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	North America/General specs	2.0L LF	IC(Instrument Cluster)																																
ROADSTERMX-5	North America/General specs	2.0L LF	RCM(Restraint Control Module)																																
ROADSTERMX-5	North America/General specs	2.0L LF	RHT(Retractable Hard Top)																																
ROADSTERMX-5	North America/General specs	2.0L LF	RKE(Remote Keyless Entry)																																
ROADSTERMX-5	North America/General specs	2.0L LF	TCM(Transmission Control Module)																																
ROADSTERMX-5	North America/General specs	2.0L LF	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
ROADSTERMX-5	North America/General specs	2.0L LF	DHS(Deployable Hood System)																																
ROADSTERMX-5	North America/General specs	1.5L P5	SYSTEM SEARCH																																
ROADSTERMX-5	North America/General specs	1.5L P5	PCM(Powertrain Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	ABS(Anti-Lock Brake System)						V																										
ROADSTERMX-5	North America/General specs	1.5L P5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)							V	V																								
ROADSTERMX-5	North America/General specs	1.5L P5	AM(Amplifier Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	DCDC(DC to DC Converter Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	EATC(Electronic Automatic Temperature Control)									V	V	V	V	V	V																		
ROADSTERMX-5	North America/General specs	1.5L P5	EPS(Electronic-Controlled Power Steering)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
ROADSTERMX-5	North America/General specs	1.5L P5	EVP(Electronical VACUUM PUMP)																																
ROADSTERMX-5	North America/General specs	1.5L P5	IC(Instrument Cluster)																																
ROADSTERMX-5	North America/General specs	1.5L P5	RCM(Restraint Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	TCM(Transmission Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	BSM(Blind Spot Monitoring)																																
ROADSTERMX-5	North America/General specs	1.5L P5	BCM(Body Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	FSC(Forward Sensing Camera)															V																	
ROADSTERMX-5	North America/General specs	1.5L P5	SSU(Smart Start Unit)																																
ROADSTERMX-5	North America/General specs	1.5L P5	CMU(Connectivity Master Unit)																																
ROADSTERMX-5	North America/General specs	1.5L P5	ESU(Electric Supply Unit)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	PCM(Powertrain Control Module)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	IC(Instrument Cluster)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	RCM(Restraint Control Module)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	RHT(Retractable Hard Top)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	RKE(Remote Keyless Entry)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	TCM(Transmission Control Module)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
ROADSTERMX-5	Europe/General Specs	2.0L LF	DHS(Deployable Hood System)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	PCM(Powertrain Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	IC(Instrument Cluster)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	RCM(Restraint Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	RHT(Retractable Hard Top)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	RKE(Remote Keyless Entry)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	TCM(Transmission Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
ROADSTERMX-5	Europe/General Specs	1.5L P5	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	PCM(Powertrain Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	ABS(Anti-Lock Brake System)						V																										
ROADSTERMX-5	Europe/General Specs	1.5L P5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)							V	V																								
ROADSTERMX-5	Europe/General Specs	1.5L P5	AM(Amplifier Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	DCDC(DC to DC Converter Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	EATC(Electronic Automatic Temperature Control)									V	V	V	V	V	V																		
ROADSTERMX-5	Europe/General Specs	1.5L P5	EPS(Electronic-Controlled Power Steering)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	EVP(Electronical VACUUM PUMP)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	IC(Instrument Cluster)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	RCM(Restraint Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	TCM(Transmission Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
ROADSTERMX-5	Europe/General Specs	1.5L P5	BSM(Blind Spot Monitoring)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	BCM(Body Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	FSC(Forward Sensing Camera)															V																	
ROADSTERMX-5	Europe/General Specs	1.5L P5	SSU(Smart Start Unit)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	CMU(Connectivity Master Unit)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	ESU(Electric Supply Unit)																																
RX-8	North America Spec	13B	SYSTEM SEARCH																																
RX-8	North America Spec	13B	PCM(Powertrain Control Module)																																
RX-8	North America Spec	13B	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
RX-8	North America Spec	13B	ABS(Anti-Lock Brake System)																																
RX-8	North America Spec	13B	EPS(Electronic-Controlled Power Steering)																																
RX-8	North America Spec	13B	IC(Instrument Cluster)																																
RX-8	North America Spec	13B	RCM(Restraint Control Module)																																
RX-8	North America Spec	13B	RKE(Remote Keyless Entry)																																
RX-8	North America Spec	13B	TCM(Transmission Control Module)																																
RX-8	North America Spec	13B	TPM(Tire Pressure Monitor)																																
RX-8	North America Spec	13B	LCM(Lighting Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	SYSTEM SEARCH																																
RX-8	North America Spec	13B-MSP High-Power	PCM(Powertrain Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
RX-8	North America Spec	13B-MSP High-Power	ABS(Anti-Lock Brake System)																																
RX-8	North America Spec	13B-MSP High-Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	North America Spec	13B-MSP High-Power	IC(Instrument Cluster)																																
RX-8	North America Spec	13B-MSP High-Power	RCM(Restraint Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	RKE(Remote Keyless Entry)																																
RX-8	North America Spec	13B-MSP High-Power	TCM(Transmission Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	TPM(Tire Pressure Monitor)																																
RX-8	North America Spec	13B-MSP Standard-Power	SYSTEM SEARCH																																
RX-8	North America Spec	13B-MSP Standard-Power	PCM(Powertrain Control Module)																																
RX-8	North America Spec	13B-MSP Standard-Power	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
RX-8	North America Spec	13B-MSP Standard-Power	ABS(Anti-Lock Brake System)																																
RX-8	North America Spec	13B-MSP Standard-Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	North America Spec	13B-MSP Standard-Power	IC(Instrument Cluster)																																
RX-8	North America Spec	13B-MSP Standard-Power	RCM(Restraint Control Module)																																
RX-8	North America Spec	13B-MSP Standard-Power	RKE(Remote Keyless Entry)																																
RX-8	North America Spec	13B-MSP Standard-Power	TCM(Transmission Control Module)																																
RX-8	North America Spec	13B-MSP Standard-Power	TPM(Tire Pressure Monitor)																																
RX-8	General	13B	SYSTEM SEARCH																																
RX-8	General	13B	PCM(Powertrain Control Module)																																
RX-8	General	13B	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
RX-8	General	13B	ABS(Anti-Lock Brake System)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
RX-8	General	13B	EPS(Electronic-Controlled Power Steering)																																
RX-8	General	13B	IC(Instrument Cluster)																																
RX-8	General	13B	RCM(Restraint Control Module)																																
RX-8	General	13B	RKE(Remote Keyless Entry)																																
RX-8	General	13B	TCM(Transmission Control Module)																																
RX-8	General	13B MSP High Power	SYSTEM SEARCH																																
RX-8	General	13B MSP High Power	PCM(Powertrain Control Module)																																
RX-8	General	13B MSP High Power	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
RX-8	General	13B MSP High Power	ABS(Anti-Lock Brake System)																																
RX-8	General	13B MSP High Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	General	13B MSP High Power	IC(Instrument Cluster)																																
RX-8	General	13B MSP High Power	RCM(Restraint Control Module)																																
RX-8	General	13B MSP High Power	RKE(Remote Keyless Entry)																																
RX-8	General	13B MSP High Power	TCM(Transmission Control Module)																																
RX-8	General	13B MSP Standard Power	SYSTEM SEARCH																																
RX-8	General	13B MSP Standard Power	PCM(Powertrain Control Module)																																
RX-8	General	13B MSP Standard Power	PATS(Passive anti theft system)-Beta																		V	V	V	V	V	V	V	V	V						
RX-8	General	13B MSP Standard Power	ABS(Anti-Lock Brake System)																																
RX-8	General	13B MSP Standard Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	General	13B MSP Standard Power	IC(Instrument Cluster)																																
RX-8	General	13B MSP Standard Power	RCM(Restraint Control Module)																																
RX-8	General	13B MSP Standard Power	RKE(Remote Keyless Entry)																																
RX-8	General	13B MSP Standard Power	TCM(Transmission Control Module)																																
ESCAPETRIBUTE	Up to 2004	SYSTEM SEARCH																																	
ESCAPETRIBUTE	Up to 2004	PCM(PowerTrain Control Module)																																	
ESCAPETRIBUTE	Up to 2004	Immobilizer																									V	V	V						
ESCAPETRIBUTE	Up to 2004	ABS(Anti-Lock Brake System)																																	
ESCAPETRIBUTE	Up to 2004	RCM(Restraint Control Module)																																	
ESCAPETRIBUTE	Up to 2004	GEM(Generic Electronic Module)																																	
ESCAPETRIBUTE	From 2004	SYSTEM SEARCH																																	
ESCAPETRIBUTE	From 2004	PCM(PowerTrain Control Module)																																	
ESCAPETRIBUTE	From 2004	PATS(Passive anti theft system)																																	
ESCAPETRIBUTE	From 2004	ABS(Anti-Lock Brake System)																																	
ESCAPETRIBUTE	From 2004	RCM(Restraint Control Module)																																	
ESCAPETRIBUTE	From 2004	IC(Instrument Cluster)																																	
ESCAPETRIBUTE	From 2004	GEM(Generic Electronic Module)																																	
General(ALL Model)	16PIN CONNECTOR	SYSTEM SEARCH																																	
General(ALL Model)	16PIN CONNECTOR	PCM(PowerTrain Control Module)																																	
General(ALL Model)	16PIN CONNECTOR	PATS(Passive anti theft system)-Beta																			V	V	V	V	V	V	V	V	V						
General(ALL Model)	16PIN CONNECTOR	TCM(Transmission Control Module)																																	
General(ALL Model)	16PIN CONNECTOR	ABS(Anti-Lock Brake System)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
General(ALL Model)	16PIN CONNECTOR	RCM(Restraint Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	SYSTEM SEARCH																																	
General(ALL Model)	17PIN CONNECTOR	PCM(PowerTrain Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	TCM(Transmission Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	ABS(Anti-Lock Brake System)																																	
General(ALL Model)	17PIN CONNECTOR	RCM(Restraint Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	PCM(PowerTrain Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	TCM(Transmission Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	RCM(Restraint Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ABS(Anti-Lock Brake System)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ACCM(Air Conditioning Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	4WS(4 Wheel Steering)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ICCM(Intelligent Cruise Control Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RCM(Restraint Control Module)																											V					
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RKE(Remote Keyless Entry)(WithSKE)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RKE(Remote Keyless Entry)(WIthout SKE)																					V	V										
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	VSM(Vehicle Security Module)																																
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	ASM																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	AT																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	PowerShift																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 (Low Power without DPF)	ASM																														

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 (Low Power without DPF)	ALL																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 + DPF (High Power with DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 3(High Power without DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 4(Low Power without DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 4 + DPF (High Power with DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 3(High Power without DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	FACM(Fuel Additive Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	1.6 Z6	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	GEM(Generic Electronic Module)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	ASM																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	AT																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	PowerShift																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	RCM(Restraint Control Module)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	FFH(Fuel Fired Coolant Heating Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	ASM																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	AT																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	PowerShift																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA GASOLINE ENGINE	PCM(Powertrain Control Module)																																	
BETA-ETC	MAZDA DIESEL ENGINE	PCM(Powertrain Control Module)																		V															
BETA-ETC	MAZDA 2 ENGINE	PCM(Powertrain Control Module)																																	
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	ABS(Anti-Lock Brake System)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	RCM(Restraint Control Module)																																
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	SYSTEM SEARCH																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	PCM(Powertrain Control Module)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	ABS(Anti-Lock Brake System)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	EPS(Electronic-Controlled Power Steering)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	IC(Instrument Cluster)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	4x4(4x4 Control Module)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	RCM(Restraint Control Module)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	RKE(Remote Keyless Entry)																																	
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	SYSTEM SEARCH																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	PCM(Powertrain Control Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	ABS(Anti-Lock Brake System)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	IC(Instrument Cluster)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	RCM(Restraint Control Module)																											V					
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	RKE(Remote Keyless Entry)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	VSM(Vehicle Security Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	TCM(Transmission Control Module)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	EPS(Electronic-Controlled Power Steering)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	GEM(Generic Electronic Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	RCM(Restraint Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	RKE(Remote Keyless Entry)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	RKE(Remote Keyless Entry)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	TCM(Transmission Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	RCM(Restraint Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	MID(Multi-Information Display)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	PCM(Powertrain Control Module)																V															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	RCM(Restraint Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	MID(Multi-Information Display)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	EATC(Electronic Automatic Temperature Control)									V																						
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	ABS(Anti-Lock Brake System)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	RKE(Remote Keyless Entry)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	TCM(Transmission Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	SYSTEM SEARCH																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	PCM(Powertrain Control Module)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	IC(Instrument Cluster)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 3 (North America/General)	SYSTEM SEARCH																																	
BETA-ETC	MAZDA 3 (North America/General)	PCM(Powertrain Control Module)																																	
BETA-ETC	MAZDA 3 (North America/General)	ABS(Anti-Lock Brake System)																																	
BETA-ETC	MAZDA 3 (North America/General)	IC(Instrument Cluster)																																	
BETA-ETC	MAZDA 3 (North America/General)	TPM(Tire Pressure Monitor)																																	
BETA-ETC	MAZDA 3 (China/General)	1.6L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	RKE(Remote Keyless Entry)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	SYSTEM SEARCH																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	PCM(Powertrain Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	ABS(Anti-Lock Brake System)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	IC(Instrument Cluster)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	GEM(Generic Electronic Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RCM(Restraint Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	LPSDM(Left Power Sliding Door Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RPSDM(Right Power Sliding Door Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	TCM(Transmission Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RKE(Remote Keyless Entry)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	PCM(Powertrain Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	ABS(Anti-Lock Brake System)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	IC(Instrument Cluster)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	GEM(Generic Electronic Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RCM(Restraint Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	LPSDM(Left Power Sliding Door Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RPSDM(Right Power Sliding Door Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	TCM(Transmission Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	TPM(Tire Pressure Monitor)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	PCM(Powertrain Control Module)	ALL																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	LHID(Left High Intensity Discharge Lamp)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	PCM(Powertrain Control Module)	ALL																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	GEM(Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	LHID(Left High Intensity Discharge Lamp)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RHID(Right High Intensity Discharge Lamp)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	TCM(Transmission Control Module)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	SYSTEM SEARCH																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	PCM(Powertrain Control Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	ABS(Anti-Lock Brake System)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	GEM(Generic Electronic Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	IC(Instrument Cluster)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	LHID(Left High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RHID(Right High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RCM(Restraint Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RKE(Remote Keyless Entry)																					V	V	V									
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	TCM(Transmission Control Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	SYSTEM SEARCH																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	PCM(Powertrain Control Module)	ALL																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	PCM(Powertrain Control Module)	MT																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	GEM(Generic Electronic Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	LHID(Left High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RHID(Right High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	IC(Instrument Cluster)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RCM(Restraint Control Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RKE(Remote Keyless Entry)																					V	V	V									
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	IC(Instrument Cluster)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	FFH(Fuel Fired Coolant Heating Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RCM(Restraint Control Module)																											V					
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	PCM(Powertrain Control Module)-ALL																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	TPM(Tire Pressure Monitor)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	TPM(Tire Pressure Monitor)																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	FFH(Fuel Fired Coolant Heating Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	RCM(Restraint Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	GEM(Generic Electronic Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	HCM(Headlamp Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	ICCM(Intelligent Cruise Control Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	IC(Instrument Cluster)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	LTM(Liftgate/Trunk Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	RCM(Restraint Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	RKE(Remote Keyless Entry)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	GEM(Generic Electronic Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	HCM(Headlamp Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	ICCM(Intelligent Cruise Control Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	IC(Instrument Cluster)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LTM(Liftgate/Trunk Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RCM(Restraint Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RKE(Remote Keyless Entry)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LCM(Lighting Control Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	4x4(4x4 Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LPSDM(Left Power Sliding Door Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RPSDM(Right Power Sliding Door Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Electronic throttle body initialization	Turbo charger initialization	Coupling Calibration Data Writing	TPMS Reset	Auto Leveling Sensor Calibration	Auto Leveling Actuator Test	Air Conditioning Compressor	Air Intake Actuator	Airflow Mode Actuator	Electrical Water Pump(For EATC)	Rear Vent Actuator	Rear Blower Motor Speed	Forward Sensing Camera Aiming	EGR Valve initialization	O2 Sensor Reset	Special service mode	Program additional advanced keys	Advanced key erase and program	Steering lock unit programming	Customer spare key Programming Enable	Customer spare key Programming Disable	Ignitions keys earse and reprogram	Additional ignition keys	Remote programming mode	RCM Installation	Urea Hose Leak Test	Urea Injector Test	Urea Pump Test	IC Warning Lamp/Chimes	IC Installation
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	SYSTEM SEARCH																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	PCM(Powertrain Control Module)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	ABS(Anti-Lock Brake System)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	IC(Instrument Cluster)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	TCM(Transmission Control Module)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	SYSTEM SEARCH																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	2005~																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	~2005																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	TCM(Transmission Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	SYSTEM SEARCH																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	PCM(Powertrain Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	ABS(Anti-Lock Brake System)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	RCM(Restraint Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	TCM(Transmission Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	SYSTEM SEARCH																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	PCM(Powertrain Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	ABS(Anti-Lock Brake System)																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	TCM(Transmission Control Module)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	PCM(Powertrain Control Module)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	ABS(Anti-Lock Brake System)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	GEM(Generic Electronic Module)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	IC(Instrument Cluster)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	RCM(Restraint Control Module)																																
BETA-ETC	TITAN DASH	2.0L RF_T	SYSTEM SEARCH																																
BETA-ETC	TITAN DASH	2.0L RF_T	PCM(Powertrain Control Module)																																
BETA-ETC	TITAN DASH	2.0L RF_T	TCM(Transmission Control Module)																																
BETA-ETC	PATS(Passive anti theft system)																				V	V	V	V	V	V	V	V	V						
BETA-ETC	Vehicle Log Capture																																		

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
Incode Calculator	Incode Calculator	~2010.05																																	
Service Manual	Reset the Oil Change Indicator(G-scan Support)																																		
Service Manual	Oil Light Reset / Service Light Reset(Manual)																																		
Service Manual	Throttle Body Learning																																		
BIANTE	2.0L LF	SYSTEM SEARCH																																	
BIANTE	2.0L LF	PCM(Powertrain Control Module)																																	
BIANTE	2.0L LF	ABS(Anti-Lock Brake System)																																	
BIANTE	2.0L LF	EATC(Electronic Automatic Temperature Control)																																	
BIANTE	2.0L LF	EPS(Electronic-Controlled Power Steering)																																	
BIANTE	2.0L LF	GEM(Generic Electronic Module)																																	
BIANTE	2.0L LF	IC(Instrument Cluster)																																	
BIANTE	2.0L LF	LPSDM(Left Power Sliding Door Module)																																	
BIANTE	2.0L LF	RCM(Restraint Control Module)																																	
BIANTE	2.0L LF	RKE(Remote Keyless Entry)																																	
BIANTE	2.0L LF	RPSDM(Right Power Sliding Door Module)																																	
BIANTE	2.0L LF	TCM(Transmission Control Module)																																	
BIANTE	2.3L L3	SYSTEM SEARCH																																	
BIANTE	2.3L L3	PCM(Powertrain Control Module)																																	
BIANTE	2.3L L3	ABS(Anti-Lock Brake System)																																	
BIANTE	2.3L L3	EATC(Electronic Automatic Temperature Control)																																	
BIANTE	2.3L L3	EPS(Electronic-Controlled Power Steering)																																	
BIANTE	2.3L L3	GEM(Generic Electronic Module)																																	
BIANTE	2.3L L3	IC(Instrument Cluster)																																	
BIANTE	2.3L L3	LPSDM(Left Power Sliding Door Module)																																	
BIANTE	2.3L L3	RCM(Restraint Control Module)																																	
BIANTE	2.3L L3	RKE(Remote Keyless Entry)																																	
BIANTE	2.3L L3	RPSDM(Right Power Sliding Door Module)																																	
BIANTE	2.3L L3	TCM(Transmission Control Module)																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	SYSTEM SEARCH																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	2005~																																
BONGOBRAWNYSPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	~2005																																
BONGOBRAWNYSPECTRON	2.0L RF_T	ABS(Anti-Lock Brake System)																																	
BONGOBRAWNYSPECTRON	2.0L RF_T	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.2 Diesel	SYSTEM SEARCH																																	
BT-50(RANGER)	2.2 Diesel	PCM(PowerTrain Control Module)																																	
BT-50(RANGER)	2.2 Diesel	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	2.2 Diesel	ACM(Audio Control Module)																																	
BT-50(RANGER)	2.2 Diesel	BCMii(Body Control Module)																																	
BT-50(RANGER)	2.2 Diesel	DDM(Drivers Door Module)																																	
BT-50(RANGER)	2.2 Diesel	FCDIM(Front Control/Display Interface Module)																																	
BT-50(RANGER)	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BT-50(RANGER)	2.2 Diesel	IPC(Instrument Panel Control Module)																																	
BT-50(RANGER)	2.2 Diesel	PAM(Parking Aid Module)																																	
BT-50(RANGER)	2.2 Diesel	PDM(Passengers Door Module)																																	
BT-50(RANGER)	2.2 Diesel	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.2 Diesel	SRM(Speech Recognition Module)																																	
BT-50(RANGER)	2.2 Diesel	TBM(Tracking And Blocking Module)																																	
BT-50(RANGER)	2.2 Diesel	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.2 Diesel	TRM(Trailer Module)																																	
BT-50(RANGER)	2.2 Diesel	PATS(Passive anti theft system)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																																	
BT-50(RANGER)	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)																																	
BT-50(RANGER)	3.2 Diesel	SYSTEM SEARCH																																	
BT-50(RANGER)	3.2 Diesel	PCM(PowerTrain Control Module)																																	
BT-50(RANGER)	3.2 Diesel	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	3.2 Diesel	ACM(Audio Control Module)																																	
BT-50(RANGER)	3.2 Diesel	BCMii(Body Control Module)																																	
BT-50(RANGER)	3.2 Diesel	DDM(Drivers Door Module)																																	
BT-50(RANGER)	3.2 Diesel	FCDIM(Front Control/Display Interface Module)																																	
BT-50(RANGER)	3.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																	
BT-50(RANGER)	3.2 Diesel	IPC(Instrument Panel Control Module)																																	
BT-50(RANGER)	3.2 Diesel	PAM(Parking Aid Module)																																	
BT-50(RANGER)	3.2 Diesel	PDM(Passengers Door Module)																																	
BT-50(RANGER)	3.2 Diesel	RCM(Restraint Control Module)																																	
BT-50(RANGER)	3.2 Diesel	SRM(Speech Recognition Module)																																	
BT-50(RANGER)	3.2 Diesel	TBM(Tracking And Blocking Module)																																	
BT-50(RANGER)	3.2 Diesel	TCM(Transmission Control Module)																																	
BT-50(RANGER)	3.2 Diesel	TRM(Trailer Module)																																	
BT-50(RANGER)	3.2 Diesel	PATS(Passive anti theft system)																																	
BT-50(RANGER)	2.3 Gasoline	PCM(Powertrain Control Module)																																	
BT-50(RANGER)	2.3 Gasoline	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	2.3 Gasoline	GEM(Generic Electronic Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initializze the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BT-50(RANGER)	2.3 Gasoline	IC(Instrument Cluster)																																	
BT-50(RANGER)	2.3 Gasoline	OCSM(Occupant Classification System Module)																																	
BT-50(RANGER)	2.3 Gasoline	4x4(4x4 Control Module)																																	
BT-50(RANGER)	2.3 Gasoline	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.3 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																	
BT-50(RANGER)	2.3 Gasoline	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	2.5 Gasoline	PCM(PowerTrain Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	2.5 Gasoline	ACM(Audio Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	BCMii(Body Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	DDM(Drivers Door Module)																																	
BT-50(RANGER)	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																																	
BT-50(RANGER)	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																																	
BT-50(RANGER)	2.5 Gasoline	IPC(Instrument Panel Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	PAM(Parking Aid Module)																																	
BT-50(RANGER)	2.5 Gasoline	PDM(Passengers Door Module)																																	
BT-50(RANGER)	2.5 Gasoline	RCM(Restraint Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	SRM(Speech Recognition Module)																																	
BT-50(RANGER)	2.5 Gasoline	TBM(Tracking And Blocking Module)																																	
BT-50(RANGER)	2.5 Gasoline	TCM(Transmission Control Module)																																	
BT-50(RANGER)	2.5 Gasoline	TRM(Trailer Module)																																	
BT-50(RANGER)	2.5 Gasoline	PATS(Passive anti theft system)																																	
BT-50(RANGER)	3.0 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	3.0 Gasoline	PCM(Powertrain Control Module)																																	
BT-50(RANGER)	3.0 Gasoline	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	3.0 Gasoline	GEM(Generic Electronic Module)																																	
BT-50(RANGER)	3.0 Gasoline	IC(Instrument Cluster)																																	
BT-50(RANGER)	3.0 Gasoline	OCSM(Occupant Classification System Module)																																	
BT-50(RANGER)	3.0 Gasoline	4x4(4x4 Control Module)																																	
BT-50(RANGER)	3.0 Gasoline	RCM(Restraint Control Module)																																	
BT-50(RANGER)	3.0 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																	
BT-50(RANGER)	3.0 Gasoline	TCM(Transmission Control Module)																																	
BT-50(RANGER)	4.0 Gasoline	SYSTEM SEARCH																																	
BT-50(RANGER)	4.0 Gasoline	PCM(Powertrain Control Module)																																	
BT-50(RANGER)	4.0 Gasoline	ABS(Anti-Lock Brake System)																																	
BT-50(RANGER)	4.0 Gasoline	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																	
BT-50(RANGER)	4.0 Gasoline	IC(Instrument Cluster)																																	
BT-50(RANGER)	4.0 Gasoline	OCSM(Occupant Classification System Module)																																	
BT-50(RANGER)	4.0 Gasoline	4x4(4x4 Control Module)																																	
BT-50(RANGER)	4.0 Gasoline	RCM(Restraint Control Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BT-50(RANGER)	4.0 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																	
BT-50(RANGER)	4.0 Gasoline	TCM(Transmission Control Module)																																	
CX-3	1.5L S5	SYSTEM SEARCH																																	
CX-3	1.5L S5	PCM(Powertrain Control Module)																																	
CX-3	1.5L S5	TCM(Transmission Control Module)																																	
CX-3	1.5L S5	4x4(4x4 Control Module)																																	
CX-3	1.5L S5	ABS(Anti-Lock Brake System)																																	
CX-3	1.5L S5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																	
CX-3	1.5L S5	EATC(Electronic Automatic Temperature Control)																																	
CX-3	1.5L S5	EPS(Electronic-Controlled Power Steering)																																	
CX-3	1.5L S5	ESU(Electric Supply Unit)																																	
CX-3	1.5L S5	IC(Instrument Cluster)																																	
CX-3	1.5L S5	RCM(Restraint Control Module)																																	
CX-3	1.5L S5	BSM(Blind Spot Monitoring)																																	
CX-3	1.5L S5	BCM(Body Control Module)																																	
CX-3	1.5L S5	CMU(Connectivity Master Unit)																																	
CX-3	1.5L S5	FSC(Forward Sensing Camera)																																	
CX-3	1.5L S5	SSU(Smart Start Unit)																																	
CX-3	1.5L S5	SCBS(Smart City Brake Support)																																	
CX-3	1.5L S5	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-3	2.0L PE	SYSTEM SEARCH																																	
CX-3	2.0L PE	PCM(Powertrain Control Module)																																	
CX-3	2.0L PE	TCM(Transmission Control Module)																																	
CX-3	2.0L PE	4x4(4x4 Control Module)																																	
CX-3	2.0L PE	ABS(Anti-Lock Brake System)																																	
CX-3	2.0L PE	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																	
CX-3	2.0L PE	EATC(Electronic Automatic Temperature Control)																																	
CX-3	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
CX-3	2.0L PE	ESU(Electric Supply Unit)																																	
CX-3	2.0L PE	IC(Instrument Cluster)																																	
CX-3	2.0L PE	RCM(Restraint Control Module)																																	
CX-3	2.0L PE	BSM(Blind Spot Monitoring)																																	
CX-3	2.0L PE	BCM(Body Control Module)																																	
CX-3	2.0L PE	CMU(Connectivity Master Unit)																																	
CX-3	2.0L PE	FSC(Forward Sensing Camera)																																	
CX-3	2.0L PE	SSU(Smart Start Unit)																																	
CX-3	2.0L PE	SCBS(Smart City Brake Support)																																	
CX-3	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.0L PE	SYSTEM SEARCH																																	
CX-5	2.0L PE	PCM(Powertrain Control Module)																																	
CX-5	2.0L PE	TCM(Transmission Control Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initializae the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
CX-5	2.0L PE	4x4(4x4 Control Module)																																	
CX-5	2.0L PE	ABS(Anti-Lock Brake System)																																	
CX-5	2.0L PE	ACU(Audio Control Unit)																																	
CX-5	2.0L PE	EATC(Electronic Automatic Temperature Control)																																	
CX-5	2.0L PE	AM(Amplifier Module)																																	
CX-5	2.0L PE	AFS(Adaptive Front Lighting System)																																	
CX-5	2.0L PE	DSM(Drivers Seat Module)																																	
CX-5	2.0L PE	DCDC(DC to DC Converter Control Module)																																	
CX-5	2.0L PE	FSC(Forward Sensing Camera)																																	
CX-5	2.0L PE	SCBS(Smart City Brake Support)																																	
CX-5	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
CX-5	2.0L PE	IC(Instrument Cluster)																																	
CX-5	2.0L PE	RVM(Rear Vehicle Monitoring)																																	
CX-5	2.0L PE	RCM(Restraint Control Module)																																	
CX-5	2.0L PE	SSU(Smart Start Unit)																																	
CX-5	2.0L PE	BSM(Blind Spot Monitoring)																																	
CX-5	2.0L PE	F_BCM(Front Body Control Module)																																	
CX-5	2.0L PE	R_BCM(Rear Body Control Module)																																	
CX-5	2.2L SH	SYSTEM SEARCH																																	
CX-5	2.2L SH	PCM(Powertrain Control Module)																																	
CX-5	2.2L SH	TCM(Transmission Control Module)																																	
CX-5	2.2L SH	4x4(4x4 Control Module)																																	
CX-5	2.2L SH	ABS(Anti-Lock Brake System)																																	
CX-5	2.2L SH	ACU(Audio Control Unit)																																	
CX-5	2.2L SH	CMU(Connectivity Master Unit)																																	
CX-5	2.2L SH	EATC(Electronic Automatic Temperature Control)																																	
CX-5	2.2L SH	AM(Amplifier Module)																																	
CX-5	2.2L SH	AFS(Adaptive Front Lighting System)																																	
CX-5	2.2L SH	DSM(Drivers Seat Module)																																	
CX-5	2.2L SH	DCDC(DC to DC Converter Control Module)																																	
CX-5	2.2L SH	FSC(Forward Sensing Camera)																																	
CX-5	2.2L SH	SCBS(Smart City Brake Support)																																	
CX-5	2.2L SH	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.2L SH	EPB(Electonic Parking Brake)																																	
CX-5	2.2L SH	EPS(Electronic-Controlled Power Steering)																																	
CX-5	2.2L SH	IC(Instrument Cluster)																																	
CX-5	2.2L SH	RVM(Rear Vehicle Monitoring)																																	
CX-5	2.2L SH	RCM(Restraint Control Module)																																	
CX-5	2.2L SH	SSU(Smart Start Unit)																																	
CX-5	2.2L SH	BSM(Blind Spot Monitoring)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
CX-5	2.2L SH	F_BCM(Front Body Control Module)																																	
CX-5	2.2L SH	R_BCM(Rear Body Control Module)																																	
CX-5	2.5L PY	SYSTEM SEARCH																																	
CX-5	2.5L PY	PCM(Powertrain Control Module)																																	
CX-5	2.5L PY	TCM(Transmission Control Module)																																	
CX-5	2.5L PY	4x4(4x4 Control Module)																																	
CX-5	2.5L PY	ABS(Anti-Lock Brake System)																																	
CX-5	2.5L PY	AM(Amplifier Module)																																	
CX-5	2.5L PY	DSM(Drivers Seat Module)																																	
CX-5	2.5L PY	EATC(Electronic Automatic Temperature Control)																																	
CX-5	2.5L PY	EPB(Electonic Parking Brake)																																	
CX-5	2.5L PY	EPS(Electronic-Controlled Power Steering)																																	
CX-5	2.5L PY	IC(Instrument Cluster)																																	
CX-5	2.5L PY	RCM(Restraint Control Module)																																	
CX-5	2.5L PY	AFS(Adaptive Front Lighting System)																																	
CX-5	2.5L PY	FSC(Forward Sensing Camera)																																	
CX-5	2.5L PY	SSU(Smart Start Unit)																																	
CX-5	2.5L PY	BSM(Blind Spot Monitoring)-JAPAN																																	
CX-5	2.5L PY	BSML(Blind Spot Monitoring Left)																																	
CX-5	2.5L PY	BSMR(Blind Spot Monitoring Right)																																	
CX-5	2.5L PY	F_BCM(Front Body Control Module)																																	
CX-5	2.5L PY	R_BCM(Rear Body Control Module)																																	
CX-5	2.5L PY	SCBS(Smart City Brake Support)																																	
CX-5	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
CX-5	2.5L PY	ACU(Audio Control Unit)																																	
CX-5	2.5L PY	CMU(Connectivity Master Unit)																																	
CX-7	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
CX-7	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)																																	
CX-7	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
CX-7	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																	
CX-7	2.2L R2_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
CX-7	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
CX-7	2.2L R2_T (Diesel)	GEM(Generic Electronic Module)																																	
CX-7	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																	
CX-7	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																																	
CX-7	2.2L R2_T (Diesel)	MID(Multi-Information Display)																																	
CX-7	2.2L R2_T (Diesel)	SCR CU(Selective Catalytic Reduction)																																	
CX-7	2.2L R2_T (Diesel)	RKE(Remote Keyless Entry)																																	
CX-7	2.2L R2_T (Diesel)	RVM(Rear Vehicle Monitoring)																																	
CX-7	2.2L R2_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																	
CX-7	2.3L L3_T	SYSTEM SEARCH																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initializate the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
CX-7	2.3L L3_T	PCM(Powertrain Control Module)																																	
CX-7	2.3L L3_T	PATS(Passive anti theft system)-Beta																																	
CX-7	2.3L L3_T	ABS(Anti-Lock Brake System)																																	
CX-7	2.3L L3_T	EATC(Electronic Automatic Temperature Control)																																	
CX-7	2.3L L3_T	AM(Amplifier Module)																																	
CX-7	2.3L L3_T	GEM(Generic Electronic Module)																																	
CX-7	2.3L L3_T	IC(Instrument Cluster)																																	
CX-7	2.3L L3_T	RCM(Restraint Control Module)																																	
CX-7	2.3L L3_T	TCM(Transmission Control Module)				V																													
CX-7	2.3L L3_T	ACU(Audio Control Unit)																																	
CX-7	2.3L L3_T	4*4(4*4 Control Module)																																	
CX-7	2.3L L3_T	MID(Multi-Information Display)																																	
CX-7	2.3L L3_T	RKE(Remote Keyless Entry)																																	
CX-7	2.3L L3_T	LCM(Lighting Control Module)																																	
CX-7	2.3L L3_T	RVM(Rear Vehicle Monitoring)																																	
CX-7	2.5L L5	SYSTEM SEARCH																																	
CX-7	2.5L L5	PCM(Powertrain Control Module)																																	
CX-7	2.5L L5	PATS(Passive anti theft system)-Beta																																	
CX-7	2.5L L5	TCM(Transmission Control Module)																																	
CX-7	2.5L L5	ABS(Anti-Lock Brake System)																																	
CX-7	2.5L L5	RCM(Restraint Control Module)																																	
CX-7	2.5L L5	GEM(Generic Electronic Module)																																	
CX-7	2.5L L5	IC(Instrument Cluster)																																	
CX-7	2.5L L5	MID(Multi-Information Display)-Beta Test																																	
CX-7	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	
CX-7	2.5L L5	ACU(Audio Control Unit)																																	
CX-7	2.5L L5	ICCM(Intelligent Cruise Control Module)																																	
CX-7	2.5L L5	RKE(Remote Keyless Entry)																																	
CX-7	2.5L L5	RVM(Rear Vehicle Monitoring)																																	
CX-7	2.5L L5	LCM(Lighting Control Module)																																	
CX-9	3.7L CA	SYSTEM SEARCH																																	
CX-9	3.7L CA	PCM(Powertrain Control Module)																																	
CX-9	3.7L CA	PATS(Passive anti theft system)-Beta																																	
CX-9	3.7L CA	ABS(Anti-Lock Brake System)					V	V																											
CX-9	3.7L CA	4WD(Four Wheel Drive)-Beta Test																																	
CX-9	3.7L CA	DSM(Drivers Seat Module)																																	
CX-9	3.7L CA	GEM(Generic Electronic Module)																																	
CX-9	3.7L CA	IC(Instrument Cluster) - Without Tire Pressure Monitor																																	
CX-9	3.7L CA	IC(Instrument Cluster) - With Tire Pressure Monitor-Beta Test							V	V																									
CX-9	3.7L CA	LCM(Lighting Control Module)-Beta Test																																	
CX-9	3.7L CA	LTM(Liftgate/Trunk Module)-Beta Test																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initializae the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
CX-9	3.7L CA	RCM(Restraint Control Module) - Except USA									V																								
CX-9	3.7L CA	RCM(Restraint Control Module) - USA-Beta Test									V																								
CX-9	3.7L CA	RKE(Remote Keyless Entry)-Beta Test																																	
CX-9	3.7L CA	TCM(Transmission Control Module)				V																													
CX-9	3.7L CA	BSML(Blind Spot Monitoring Left)-Beta Test																																	
CX-9	3.7L CA	BSMR(Blind Spot Monitoring Right)-Beta Test																																	
CX-9	3.5L CY-Beta Test	SYSTEM SEARCH																																	
CX-9	3.5L CY-Beta Test	PCM(Powertrain Control Module)																																	
CX-9	3.5L CY-Beta Test	PATS(Passive anti theft system)-Beta																																	
CX-9	3.5L CY-Beta Test	ABS(Anti-Lock Brake System)					V	V																											
CX-9	3.5L CY-Beta Test	4WD(Four Wheel Drive)																																	
CX-9	3.5L CY-Beta Test	GEM(Generic Electronic Module)																																	
CX-9	3.5L CY-Beta Test	IC(Instrument Cluster) - Without Tire Pressure Monitor																																	
CX-9	3.5L CY-Beta Test	IC(Instrument Cluster) - With Tire Pressure Monitor							V	V																									
CX-9	3.5L CY-Beta Test	LTM(Liftgate/Trunk Module)																																	
CX-9	3.5L CY-Beta Test	RCM(Restraint Control Module) - USA									V																								
CX-9	3.5L CY-Beta Test	RKE(Remote Keyless Entry)																																	
CX-9	3.5L CY-Beta Test	TCM(Transmission Control Module)				V																													
DEMIOVERISAMAZDA2	1.3L ZJ	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.3L ZJ	PCM(Powertrain Control Module)										V	V	V	V																				
DEMIOVERISAMAZDA2	1.3L ZJ	PATS(Passive anti theft system)-Beta																																	
DEMIOVERISAMAZDA2	1.3L ZJ	ABS(Anti-Lock Brake System)														V	V	V	V																
DEMIOVERISAMAZDA2	1.3L ZJ	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.3L ZJ	EPS(Electronic-Controlled Power Steering)																		V	V	V	V												
DEMIOVERISAMAZDA2	1.3L ZJ	RKE(Remote Keyless Entry)																																	
DEMIOVERISAMAZDA2	1.3L P3	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.3L P3	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	ABS(Anti-Lock Brake System)														V	V																		
DEMIOVERISAMAZDA2	1.3L P3	BCM(Body Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	EATC(Electronic Automatic Temperature Control)																																	
DEMIOVERISAMAZDA2	1.3L P3	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.3L P3	FSC(Forward Sensing Camera)																																	
DEMIOVERISAMAZDA2	1.3L P3	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.3L P3	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	SSU(Smart Start Unit)																																	
DEMIOVERISAMAZDA2	1.3L P3	SCBS(Smart City Brake Support)																																	
DEMIOVERISAMAZDA2	1.3L P3	ALM(Auto Leveling Module)																																	
DEMIOVERISAMAZDA2	1.3L P3	BSM(Blind Spot Monitoring)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
DEMIOVERISAMAZDA2	1.3L P3	CMU(Connectivity Master Unit)																																	
DEMIOVERISAMAZDA2	1.3L P3	ESU(Electric Supply Unit)																																	
DEMIOVERISAMAZDA2	1.5L ZY	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L ZY	PCM(Powertrain Control Module)										V	V	V	V																				
DEMIOVERISAMAZDA2	1.5L ZY	PATS(Passive anti theft system)-Beta																																	
DEMIOVERISAMAZDA2	1.5L ZY	ABS(Anti-Lock Brake System)														V	V	V	V																
DEMIOVERISAMAZDA2	1.5L ZY	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.5L ZY	EPS(Electronic-Controlled Power Steering)																		V	V	V	V												
DEMIOVERISAMAZDA2	1.5L ZY	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
DEMIOVERISAMAZDA2	1.5L ZY	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.5L ZY	RKE(Remote Keyless Entry)	With SKE																																
DEMIOVERISAMAZDA2	1.5L ZY	RKE(Remote Keyless Entry)	Without SKE																																
DEMIOVERISAMAZDA2	1.5L ZY	VSM(Vehicle Security Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L P5	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.5L P5	EATC(Electronic Automatic Temperature Control)																																	
DEMIOVERISAMAZDA2	1.5L P5	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.5L P5	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.5L P5	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	BSM(Blind Spot Monitoring)																																	
DEMIOVERISAMAZDA2	1.5L P5	BCM(Body Control Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	FSC(Forward Sensing Camera)																																	
DEMIOVERISAMAZDA2	1.5L P5	SSU(Smart Start Unit)																																	
DEMIOVERISAMAZDA2	1.5L P5	SCBS(Smart City Brake Support)																																	
DEMIOVERISAMAZDA2	1.5L P5	ALM(Auto Leveling Module)																																	
DEMIOVERISAMAZDA2	1.5L P5	CMU(Connectivity Master Unit)																																	
DEMIOVERISAMAZDA2	1.5L P5	ESU(Electric Supply Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.5L S5	PCM(Powertrain Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	TCM(Transmission Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	4x4(4x4 Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	ABS(Anti-Lock Brake System)																																	
DEMIOVERISAMAZDA2	1.5L S5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	EATC(Electronic Automatic Temperature Control)																																	
DEMIOVERISAMAZDA2	1.5L S5	EPS(Electronic-Controlled Power Steering)																																	
DEMIOVERISAMAZDA2	1.5L S5	ESU(Electric Supply Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.5L S5	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	BSM(Blind Spot Monitoring)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initializate the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
DEMIOVERISAMAZDA2	1.5L S5	BCM(Body Control Module)																																	
DEMIOVERISAMAZDA2	1.5L S5	CMU(Connectivity Master Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	FSC(Forward Sensing Camera)																																	
DEMIOVERISAMAZDA2	1.5L S5	SSU(Smart Start Unit)																																	
DEMIOVERISAMAZDA2	1.5L S5	SCBS(Smart City Brake Support)																																	
DEMIOVERISAMAZDA2	1.5L S5	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	SYSTEM SEARCH																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	PCM(Powertrain Control Module)																						V	V	V	V	V							
DEMIOVERISAMAZDA2	1.6L Y6-Beta	PATS(Passive anti theft system)-Beta																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	ABS(Anti-Lock Brake System)														V	V																		
DEMIOVERISAMAZDA2	1.6L Y6-Beta	IC(Instrument Cluster)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	EPS(Electronic-Controlled Power Steering)																		V	V	V	V												
DEMIOVERISAMAZDA2	1.6L Y6-Beta	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RCM(Restraint Control Module)																																	
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RKE(Remote Keyless Entry)	With SKE																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RKE(Remote Keyless Entry)	Without SKE																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	VSM(Vehicle Security Module)																																	
AXELAMAZDA3	1.5L ZY	SYSTEM SEARCH																																	
AXELAMAZDA3	1.5L ZY	PCM(Powertrain Control Module)											V	V	V																				
AXELAMAZDA3	1.5L ZY	ABS(Anti-Lock Brake System)														V	V												V						
AXELAMAZDA3	1.5L ZY	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	1.5L ZY	RCM(Restraint Control Module)																																	
AXELAMAZDA3	1.5L ZY	IC(Instrument Cluster)																												V					
AXELAMAZDA3	1.5L ZY	GEM(Generic Electronic Module)																																	
AXELAMAZDA3	1.5L ZY	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	1.6L Y6	SYSTEM SEARCH																																	
AXELAMAZDA3	1.6L Y6	PCM(Powertrain Control Module)																													V	V	V	V	V
AXELAMAZDA3	1.6L Y6	ABS(Anti-Lock Brake System)														V	V												V						
AXELAMAZDA3	1.6L Y6	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	1.6L Y6	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	1.6L Y6	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	1.6L Y6	FACM(Fuel Additive Control Module)																																	
AXELAMAZDA3	1.6L Y6	IC(Instrument Cluster)																												V					
AXELAMAZDA3	1.6L Y6	RCM(Restraint Control Module)																																	
AXELAMAZDA3	1.6L Y6	RKE(Remote Keyless Entry)																																	
AXELAMAZDA3	1.6L Y6	BSML(Blind Spot Monitoring Left)																																	
AXELAMAZDA3	1.6L Y6	BSMR(Blind Spot Monitoring Right)																																	
AXELAMAZDA3	1.6L Y6	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	1.6L Y6	MID(Multi-Information Display)																																	
AXELAMAZDA3	1.6L Y6	ACU(Audio Control Unit)																																	
AXELAMAZDA3	1.6L Y6	PATS(Passive anti theft system)-Beta																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
AXELAMAZDA3	1.6L Z6	SYSTEM SEARCH																																	
AXELAMAZDA3	1.6L Z6	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	1.6L Z6	ABS(Anti-Lock Brake System)														V	V											V							
AXELAMAZDA3	1.6L Z6	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	1.6L Z6	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	1.6L Z6	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	1.6L Z6	IC(Instrument Cluster)																											V						
AXELAMAZDA3	1.6L Z6	GEM(Generic Electronic Module)																																	
AXELAMAZDA3	1.6L Z6	MID(Multi-Information Display)																																	
AXELAMAZDA3	1.6L Z6	RCM(Restraint Control Module)																																	
AXELAMAZDA3	1.6L Z6	ACU(Audio Control Unit)																																	
AXELAMAZDA3	1.6L Z6	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.0L LF	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L LF	PCM(Powertrain Control Module)											V	V	V																				
AXELAMAZDA3	2.0L LF	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.0L LF	ABS(Anti-Lock Brake System)														V	V											V							
AXELAMAZDA3	2.0L LF	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.0L LF	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.0L LF	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.0L LF	IC(Instrument Cluster)																											V						
AXELAMAZDA3	2.0L LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.0L LF	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.0L LF	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.0L LF	GEM(Generic Electronic Module)																																	
AXELAMAZDA3	2.0L LF	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.0L PE	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L PE	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.0L PE	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.0L PE	4x4(4x4 Control Module)																																	
AXELAMAZDA3	2.0L PE	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.0L PE	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.0L PE	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.0L PE	AM(Amplifier Module)																																	
AXELAMAZDA3	2.0L PE	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.0L PE	DSM(Drivers Seat Module)																																	
AXELAMAZDA3	2.0L PE	DCDC(DC to DC Converter Control Module)																																	
AXELAMAZDA3	2.0L PE	FSC(Forward Sensing Camera)																																	
AXELAMAZDA3	2.0L PE	SCBS(Smart City Brake Support)																																	
AXELAMAZDA3	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
AXELAMAZDA3	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.0L PE	IC(Instrument Cluster)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
AXELAMAZDA3	2.0L PE	RVM(Rear Vehicle Monitoring)																																	
AXELAMAZDA3	2.0L PE	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.0L PE	SSU(Smart Start Unit)																																	
AXELAMAZDA3	2.0L PE	F_BCM(Front Body Control Module)																																	
AXELAMAZDA3	2.0L PE	R_BCM(Rear Body Control Module)																																	
AXELAMAZDA3	2.0L PE	CMU(Connectivity Master Unit)																																	
AXELAMAZDA3	2.3L L3_T	SYSTEM SEARCH																																	
AXELAMAZDA3	2.3L L3_T	PCM(Powertrain Control Module)											V	V	V																				
AXELAMAZDA3	2.3L L3_T	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.3L L3_T	ABS(Anti-Lock Brake System)														V	V												V						
AXELAMAZDA3	2.3L L3_T	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.3L L3_T	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.3L L3_T	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.3L L3_T	IC(Instrument Cluster)																												V					
AXELAMAZDA3	2.3L L3_T	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.3L L3_T	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.3L L3_T	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.3L L3_T	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.3L L3_T	LCM(Lighting Control Module)																																	
AXELAMAZDA3	2.3L L3_T	RKE(Remote Keyless Entry)																																	
AXELAMAZDA3	2.3L L3_T	TPM(Tire Pressure Monitor)							V	V																									
AXELAMAZDA3	2.3L L3_T	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.5L L5	SYSTEM SEARCH																																	
AXELAMAZDA3	2.5L L5	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.5L L5	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.5L L5	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.5L L5	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.5L L5	IC(Instrument Cluster)																												V					
AXELAMAZDA3	2.5L L5	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.5L L5	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.5L L5	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.5L L5	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.5L L5	RKE(Remote Keyless Entry)																																	
AXELAMAZDA3	2.5L PY	SYSTEM SEARCH																																	
AXELAMAZDA3	2.5L PY	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.5L PY	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.5L PY	4x4(4x4 Control Module)																																	
AXELAMAZDA3	2.5L PY	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.5L PY	AM(Amplifier Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
AXELAMAZDA3	2.5L PY	DSM(Drivers Seat Module)																																	
AXELAMAZDA3	2.5L PY	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.5L PY	EPB(Electonic Parking Brake)																																	
AXELAMAZDA3	2.5L PY	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.5L PY	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.5L PY	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.5L PY	AFS(Adaptive Front Lighting System)																																	
AXELAMAZDA3	2.5L PY	FSC(Forward Sensing Camera)																																	
AXELAMAZDA3	2.5L PY	SSU(Smart Start Unit)																																	
AXELAMAZDA3	2.5L PY	F_BCM(Front Body Control Module)																																	
AXELAMAZDA3	2.5L PY	R_BCM(Rear Body Control Module)																																	
AXELAMAZDA3	2.5L PY	SCBS(Smart City Brake Support)																																	
AXELAMAZDA3	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
AXELAMAZDA3	2.5L PY	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.5L PY	CMU(Connectivity Master Unit)																																	
AXELAMAZDA3	2.5L PY	BSML(Blind Spot Monitoring Left)																																	
AXELAMAZDA3	2.5L PY	BSMR(Blind Spot Monitoring Right)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.0L RF_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	MID(Multi-Information Display)																																	
AXELAMAZDA3	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
AXELAMAZDA3	2.2L SH (Diesel)	SYSTEM SEARCH																																	
AXELAMAZDA3	2.2L SH (Diesel)	PCM(Powertrain Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	TCM(Transmission Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	4x4(4x4 Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	ABS(Anti-Lock Brake System)																																	
AXELAMAZDA3	2.2L SH (Diesel)	ACU(Audio Control Unit)																																	
AXELAMAZDA3	2.2L SH (Diesel)	CMU(Connectivity Master Unit)																																	
AXELAMAZDA3	2.2L SH (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
AXELAMAZDA3	2.2L SH (Diesel)	AM(Amplifier Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	AFS(Adaptive Front Lighting System)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
AXELAMAZDA3	2.2L SH (Diesel)	DSM(Drivers Seat Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	DCDC(DC to DC Converter Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	FSC(Forward Sensing Camera)																																	
AXELAMAZDA3	2.2L SH (Diesel)	SCBS(Smart City Brake Support)																																	
AXELAMAZDA3	2.2L SH (Diesel)	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
AXELAMAZDA3	2.2L SH (Diesel)	EPB(Electonic Parking Brake)																																	
AXELAMAZDA3	2.2L SH (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
AXELAMAZDA3	2.2L SH (Diesel)	IC(Instrument Cluster)																																	
AXELAMAZDA3	2.2L SH (Diesel)	RVM(Rear Vehicle Monitoring)																																	
AXELAMAZDA3	2.2L SH (Diesel)	RCM(Restraint Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	SSU(Smart Start Unit)																																	
AXELAMAZDA3	2.2L SH (Diesel)	F_BCM(Front Body Control Module)																																	
AXELAMAZDA3	2.2L SH (Diesel)	R_BCM(Rear Body Control Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	SYSTEM SEARCH																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	PCM(Powertrain Control Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	ABS(Anti-Lock Brake System)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	EPS(Electronic-Controlled Power Steering)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	IC(Instrument Cluster)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	LPSDM(Left Power Sliding Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	RKE(Remote Keyless Entry)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	RPSDM(Right Power Sliding Module)																																	
PREMACYMAZDA5	1.6L Y6 (BETA)	ACU(Audio Control Unit)																																	
PREMACYMAZDA5	1.8L (BETA)	2005	SYSTEM SEARCH																																
PREMACYMAZDA5	1.8L (BETA)	2005	PCM(Powertrain Control Module)-MT																																
PREMACYMAZDA5	1.8L (BETA)	2005	ABS(Anti-Lock Brake System)													V	V											V							
PREMACYMAZDA5	1.8L (BETA)	2005	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	1.8L (BETA)	2005	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	1.8L (BETA)	2005	GEM(Generic Electronic Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	RCM(Restraint Control Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	IC(Instrument Cluster)																																
PREMACYMAZDA5	1.8L (BETA)	2005	LPSDM(Left Power Sliding Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	RPSDM(Right Power Sliding Module)																																
PREMACYMAZDA5	1.8L (BETA)	2005	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	1.8L (BETA)	2005	PATS(Passive anti theft system)-Beta																																
PREMACYMAZDA5	2.0L LF	2005	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2005	PCM(Powertrain Control Module)	ALL																															
PREMACYMAZDA5	2.0L LF	2005	PCM(Powertrain Control Module)	AT																															
PREMACYMAZDA5	2.0L LF	2005	ABS(Anti-Lock Brake System)													V	V																		

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
PREMACYMAZDA5	2.0L LF	2005	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.0L LF	2005	GEM(Generic Electronic Module)																																
PREMACYMAZDA5	2.0L LF	2005	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.0L LF	2005	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L LF	2005	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L LF	2005	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L LF	2005	PATS(Passive anti theft system)-Beta																																
PREMACYMAZDA5	2.0L LF	2007	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2007	PCM(Powertrain Control Module)									V		V	V																				
PREMACYMAZDA5	2.0L LF	2007	ABS(Anti-Lock Brake System)													V	V												V						
PREMACYMAZDA5	2.0L LF	2007	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.0L LF	2007	GEM(Generic Electronic Module)																																
PREMACYMAZDA5	2.0L LF	2007	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.0L LF	2007	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L LF	2007	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L LF	2007	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L LF	2007	PATS(Passive anti theft system)-Beta																																
PREMACYMAZDA5	2.0L LF	2010~	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L LF	2010~	PCM(Powertrain Control Module)																																
PREMACYMAZDA5	2.0L LF	2010~	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	2.0L LF	2010~	BCM/GEM(Body Control Module/Generic Electronic Module)																																
PREMACYMAZDA5	2.0L LF	2010~	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L LF	2010~	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.0L LF	2010~	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L LF	2010~	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L LF	2010~	LPSDM(Left Power Sliding Module)																																
PREMACYMAZDA5	2.0L LF	2010~	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.0L LF	2010~	RPSDM(Right Power Sliding Module)																																
PREMACYMAZDA5	2.0L LF	2010~	TCM(Transmission Control Module)																																
PREMACYMAZDA5	2.0L RF_T (Diesel)	SYSTEM SEARCH																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	PCM(Powertrain Control Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	TCM(Transmission Control Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	ABS(Anti-Lock Brake System)														V	V												V						
PREMACYMAZDA5	2.0L RF_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	GEM(Generic Electronic Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	IC(Instrument Cluster)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	RKE(Remote Keyless Entry)																																	
PREMACYMAZDA5	2.0L RF_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
PREMACYMAZDA5	2.3L L3	SYSTEM SEARCH																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
PREMACYMAZDA5	2.3L L3	PCM(Powertrain Control Module)																																	
PREMACYMAZDA5	2.3L L3	ABS(Anti-Lock Brake System)														V	V											V							
PREMACYMAZDA5	2.3L L3	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	2.3L L3	EPS(Electronic-Controlled Power Steering)																																	
PREMACYMAZDA5	2.3L L3	GEM(Generic Electronic Module)																																	
PREMACYMAZDA5	2.3L L3	IC(Instrument Cluster)																																	
PREMACYMAZDA5	2.3L L3	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	2.3L L3	TPM(Tire Pressure Monitor)																																	
PREMACYMAZDA5	2.5L L5	SYSTEM SEARCH																																	
PREMACYMAZDA5	2.5L L5	PCM(Powertrain Control Module)												V																					
PREMACYMAZDA5	2.5L L5	TCM(Transmission Control Module)																																	
PREMACYMAZDA5	2.5L L5	ABS(Anti-Lock Brake System)														V	V																		
PREMACYMAZDA5	2.5L L5	EPS(Electronic-Controlled Power Steering)																																	
PREMACYMAZDA5	2.5L L5	RCM(Restraint Control Module)																																	
PREMACYMAZDA5	2.5L L5	IC(Instrument Cluster)																																	
PREMACYMAZDA5	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
PREMACYMAZDA5	2.5L L5	LPSDM(Left Power Sliding Module)																																	
PREMACYMAZDA5	2.5L L5	RPSDM(Right Power Sliding Module)																																	
PREMACYMAZDA5	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	
PREMACYMAZDA5	2.5L L5	AFS(Adaptive Front Lighting System)																																	
PREMACYMAZDA5	2.5L L5	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	1.8L L8	SYSTEM SEARCH																																	
ATENZAMAZDA6	1.8L L8	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	1.8L L8	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	1.8L L8	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	1.8L L8	GEM(Generic Electronic Module)																																	
ATENZAMAZDA6	1.8L L8	IC(Instrument Cluster)																																	
ATENZAMAZDA6	1.8L L8	LHID(Left High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	1.8L L8	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	1.8L L8	RHID(Right High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	1.8L L8	RKE(Remote Keyless Entry)																																	
ATENZAMAZDA6	1.8L L8	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.0L PE	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.0L PE	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.0L PE	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.0L PE	4x4(4x4 Control Module)																																	
ATENZAMAZDA6	2.0L PE	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.0L PE	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.0L PE	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.0L PE	EPB(Electonic Parking Brake)																																	
ATENZAMAZDA6	2.0L PE	AM(Amplifier Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
ATENZAMAZDA6	2.0L PE	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.0L PE	DSM(Drivers Seat Module)																																	
ATENZAMAZDA6	2.0L PE	DCDC(DC to DC Converter Control Module)																																	
ATENZAMAZDA6	2.0L PE	FSC(Forward Sensing Camera)																																	
ATENZAMAZDA6	2.0L PE	SCBS(Smart City Brake Support)																																	
ATENZAMAZDA6	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
ATENZAMAZDA6	2.0L PE	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.0L PE	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.0L PE	RVM(Rear Vehicle Monitoring)																																	
ATENZAMAZDA6	2.0L PE	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.0L PE	SSU(Smart Start Unit)																																	
ATENZAMAZDA6	2.0L PE	F_BCM(Front Body Control Module)																																	
ATENZAMAZDA6	2.0L PE	R_BCM(Rear Body Control Module)																																	
ATENZAMAZDA6	2.0L PE	CMU(Connectivity Master Unit)																																	
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.0L LF	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.0L LF	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.0L LF	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.0L LF	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.0L LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
ATENZAMAZDA6	2.0L LF	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.0L LF	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.0L LF	GEM(Generic Electronic Module)																																	
ATENZAMAZDA6	2.0L LF	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.0L LF	LCM(Lighting Control Module)																																	
ATENZAMAZDA6	2.0L LF	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.0L LF	RHID(Right High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.0L LF	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.0L LF	LHID(Left High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.0L LF	RKE(Remote Keyless Entry)																																	
ATENZAMAZDA6	2.0L LF	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.3L L3	2.3L	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3L	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3	2.3L	IC(Instrument Cluster)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
ATENZAMAZDA6	2.3L L3	2.3L	GEM(Generic Electronic Module)																																
ATENZAMAZDA6	2.3L L3	2.3L	RHID(Right High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.3L L3	2.3L	LHID(Left High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.3L L3	2.3L	RCM(Restraint Control Module)								V																								
ATENZAMAZDA6	2.3L L3	2.3L	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.3L L3_T	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.3L L3_T	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.3L L3_T	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.3L L3_T	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.3L L3_T	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.3L L3_T	LHID(Left High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.3L L3_T	RHID(Right High Intensity Discharge Lamp)																																	
ATENZAMAZDA6	2.3L L3_T	RCM(Restraint Control Module)									V																								
ATENZAMAZDA6	2.3L L3_T	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.5L L5	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.5L L5	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.5L L5	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.5L L5	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.5L L5	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.5L L5	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.5L L5	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
ATENZAMAZDA6	2.5L L5	EATC(Electronic Automatic Temperature Control)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
ATENZAMAZDA6	2.5L L5	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.5L L5	LCM(Lighting Control Module)																																	
ATENZAMAZDA6	2.5L L5	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.5L PY	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.5L PY	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.5L PY	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.5L PY	4x4(4x4 Control Module)																																	
ATENZAMAZDA6	2.5L PY	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.5L PY	AM(Amplifier Module)																																	
ATENZAMAZDA6	2.5L PY	BSML(Blind Spot Monitoring Left)																																	
ATENZAMAZDA6	2.5L PY	BSMR(Blind Spot Monitoring Right)																																	
ATENZAMAZDA6	2.5L PY	DSM(Drivers Seat Module)																																	
ATENZAMAZDA6	2.5L PY	DCDC(DC to DC Converter Control Module)																																	
ATENZAMAZDA6	2.5L PY	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.5L PY	EPB(Electonic Parking Brake)																																	
ATENZAMAZDA6	2.5L PY	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.5L PY	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.5L PY	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.5L PY	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.5L PY	FSC(Forward Sensing Camera)																																	
ATENZAMAZDA6	2.5L PY	SSU(Smart Start Unit)																																	
ATENZAMAZDA6	2.5L PY	F_BCM(Front Body Control Module)																																	
ATENZAMAZDA6	2.5L PY	R_BCM(Rear Body Control Module)																																	
ATENZAMAZDA6	2.5L PY	SCBS(Smart City Brake Support)																																	
ATENZAMAZDA6	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
ATENZAMAZDA6	2.5L PY	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.5L PY	CMU(Connectivity Master Unit)																																	
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	FFH(Fuel Fired Coolant Heating Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	LHID(Left High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	RHID(Right High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	RCM(Restraint Control Module)								V																								
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	ACU(Audio Control Unit)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	BCM/GEM(Body Control Module/Generic Electronic Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	GEM(Generic Electronic Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	EATC(Electronic Automatic Temperature Control)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	IC(Instrument Cluster)						V	V																									
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	EPS(Electronic-Controlled Power Steering)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	FFH(Fuel Fired Coolant Heating Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	LCM(Lighting Control Module)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	RVM(Rear Vehicle Monitoring)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.2L R2_T (Diesel)	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	ACU(Audio Control Unit)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	BCM/GEM(Body Control Module/Generic Electronic Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	IC(Instrument Cluster)							V	V																									
ATENZAMAZDA6	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	LCM(Lighting Control Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																	
ATENZAMAZDA6	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SYSTEM SEARCH																																	
ATENZAMAZDA6	2.2L SH (Diesel)	PCM(Powertrain Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	TCM(Transmission Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	4x4(4x4 Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	ABS(Anti-Lock Brake System)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	AM(Amplifier Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	CMU(Connectivity Master Unit)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	EATC(Electronic Automatic Temperature Control)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	AFS(Adaptive Front Lighting System)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	DSM(Drivers Seat Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	DCDC(DC to DC Converter Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	FSC(Forward Sensing Camera)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SCBS(Smart City Brake Support)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	EPB(Electonic Parking Brake)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	EPS(Electronic-Controlled Power Steering)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	IC(Instrument Cluster)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	RVM(Rear Vehicle Monitoring)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	RCM(Restraint Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	SSU(Smart Start Unit)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	F_BCM(Front Body Control Module)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initializze the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
ATENZAMAZDA6	2.2L SH (Diesel)	R_BCM(Rear Body Control Module)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	BSM(Blind Spot Monitoring)																																	
ATENZAMAZDA6	2.2L SH (Diesel)	PSM(Parking Sensor Module)																																	
MPVMAZDA8	2.3L L3	SYSTEM SEARCH																																	
MPVMAZDA8	2.3L L3	PCM(Powertrain Control Module)										V		V	V																				
MPVMAZDA8	2.3L L3	ABS(Anti-Lock Brake System)																																	
MPVMAZDA8	2.3L L3_T	SYSTEM SEARCH																																	
MPVMAZDA8	2.3L L3_T	PCM(Powertrain Control Module)																																	
MPVMAZDA8	2.3L L3_T	ABS(Anti-Lock Brake System)																																	
MPVMAZDA8	2.3L L3_T	AM(Amplifier Module)																																	
MPVMAZDA8	2.3L L3_T	GEM(Generic Electronic Module)																																	
MPVMAZDA8	2.3L L3_T	HCM(Headlamp Control Module)																																	
MPVMAZDA8	2.3L L3_T	ICCM(Intelligent Cruise Control Module)-Beta Test																																	
MPVMAZDA8	2.3L L3_T	IC(Instrument Cluster)																																	
MPVMAZDA8	2.3L L3_T	LTM(Liftgate/Trunk Module)-Beta Test																																	
MPVMAZDA8	2.3L L3_T	RCM(Restraint Control Module)																																	
MPVMAZDA8	2.3L L3_T	RKE(Remote Keyless Entry)																																	
MPVMAZDA8	2.3L L3_T	TCM(Transmission Control Module)																																	
MPVMAZDA8	2.3L L3_T	LCM(Lighting Control Module)-Beta Test																																	
MPVMAZDA8	2.3L L3_T	4x4(4x4 Control Module)																																	
MPVMAZDA8	2.3L L3_T	LPSDM(Left Power Sliding Door Module)																																	
MPVMAZDA8	2.3L L3_T	RPSDM(Right Power Sliding Door Module)																																	
ROADSTERMX-5	North America/General specs	2.0L LF	SYSTEM SEARCH																																
ROADSTERMX-5	North America/General specs	2.0L LF	PCM(Powertrain Control Module)	2006~																															
ROADSTERMX-5	North America/General specs	2.0L LF	PCM(Powertrain Control Module)	2008~																															
ROADSTERMX-5	North America/General specs	2.0L LF	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	North America/General specs	2.0L LF	IC(Instrument Cluster)						V	V																									
ROADSTERMX-5	North America/General specs	2.0L LF	RCM(Restraint Control Module)																																
ROADSTERMX-5	North America/General specs	2.0L LF	RHT(Retractable Hard Top)																																
ROADSTERMX-5	North America/General specs	2.0L LF	RKE(Remote Keyless Entry)																																
ROADSTERMX-5	North America/General specs	2.0L LF	TCM(Transmission Control Module)																																
ROADSTERMX-5	North America/General specs	2.0L LF	PATS(Passive anti theft system)-Beta																																
ROADSTERMX-5	North America/General specs	2.0L LF	DHS(Deployable Hood System)																																
ROADSTERMX-5	North America/General specs	1.5L P5	SYSTEM SEARCH																																
ROADSTERMX-5	North America/General specs	1.5L P5	PCM(Powertrain Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	North America/General specs	1.5L P5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	AM(Amplifier Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	DCDC(DC to DC Converter Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	EATC(Electronic Automatic Temperature Control)																																
ROADSTERMX-5	North America/General specs	1.5L P5	EPS(Electronic-Controlled Power Steering)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
ROADSTERMX-5	North America/General specs	1.5L P5	EVP(Electronical VACUUM PUMP)																																
ROADSTERMX-5	North America/General specs	1.5L P5	IC(Instrument Cluster)																																
ROADSTERMX-5	North America/General specs	1.5L P5	RCM(Restraint Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	TCM(Transmission Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	BSM(Blind Spot Monitoring)																																
ROADSTERMX-5	North America/General specs	1.5L P5	BCM(Body Control Module)																																
ROADSTERMX-5	North America/General specs	1.5L P5	FSC(Forward Sensing Camera)																																
ROADSTERMX-5	North America/General specs	1.5L P5	SSU(Smart Start Unit)																																
ROADSTERMX-5	North America/General specs	1.5L P5	CMU(Connectivity Master Unit)																																
ROADSTERMX-5	North America/General specs	1.5L P5	ESU(Electric Supply Unit)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	PCM(Powertrain Control Module)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	IC(Instrument Cluster)						V	V																									
ROADSTERMX-5	Europe/General Specs	2.0L LF	RCM(Restraint Control Module)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	RHT(Retractable Hard Top)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	RKE(Remote Keyless Entry)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	TCM(Transmission Control Module)																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	PATS(Passive anti theft system)-Beta																																
ROADSTERMX-5	Europe/General Specs	2.0L LF	DHS(Deployable Hood System)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	PCM(Powertrain Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	IC(Instrument Cluster)						V	V																									
ROADSTERMX-5	Europe/General Specs	1.8L L8	RCM(Restraint Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	RHT(Retractable Hard Top)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	RKE(Remote Keyless Entry)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	TCM(Transmission Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.8L L8	PATS(Passive anti theft system)-Beta																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	SYSTEM SEARCH																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	PCM(Powertrain Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	ABS(Anti-Lock Brake System)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	AM(Amplifier Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	DCDC(DC to DC Converter Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	EATC(Electronic Automatic Temperature Control)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	EPS(Electronic-Controlled Power Steering)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	EVP(Electronical VACUUM PUMP)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	IC(Instrument Cluster)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	RCM(Restraint Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	TCM(Transmission Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
ROADSTERMX-5	Europe/General Specs	1.5L P5	BSM(Blind Spot Monitoring)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	BCM(Body Control Module)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	FSC(Forward Sensing Camera)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	SSU(Smart Start Unit)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	CMU(Connectivity Master Unit)																																
ROADSTERMX-5	Europe/General Specs	1.5L P5	ESU(Electric Supply Unit)																																
RX-8	North America Spec	13B	SYSTEM SEARCH																																
RX-8	North America Spec	13B	PCM(Powertrain Control Module)																																
RX-8	North America Spec	13B	PATS(Passive anti theft system)-Beta																																
RX-8	North America Spec	13B	ABS(Anti-Lock Brake System)																																
RX-8	North America Spec	13B	EPS(Electronic-Controlled Power Steering)																																
RX-8	North America Spec	13B	IC(Instrument Cluster)																																
RX-8	North America Spec	13B	RCM(Restraint Control Module)																																
RX-8	North America Spec	13B	RKE(Remote Keyless Entry)																																
RX-8	North America Spec	13B	TCM(Transmission Control Module)																																
RX-8	North America Spec	13B	TPM(Tire Pressure Monitor)																																
RX-8	North America Spec	13B	LCM(Lighting Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	SYSTEM SEARCH																																
RX-8	North America Spec	13B-MSP High-Power	PCM(Powertrain Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	PATS(Passive anti theft system)-Beta																																
RX-8	North America Spec	13B-MSP High-Power	ABS(Anti-Lock Brake System)																																
RX-8	North America Spec	13B-MSP High-Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	North America Spec	13B-MSP High-Power	IC(Instrument Cluster)																																
RX-8	North America Spec	13B-MSP High-Power	RCM(Restraint Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	RKE(Remote Keyless Entry)																																
RX-8	North America Spec	13B-MSP High-Power	TCM(Transmission Control Module)																																
RX-8	North America Spec	13B-MSP High-Power	TPM(Tire Pressure Monitor)																																
RX-8	North America Spec	13B-MSP Standard-Power	SYSTEM SEARCH																																
RX-8	North America Spec	13B-MSP Standard-Power	PCM(Powertrain Control Module)																																
RX-8	North America Spec	13B-MSP Standard-Power	PATS(Passive anti theft system)-Beta																																
RX-8	North America Spec	13B-MSP Standard-Power	ABS(Anti-Lock Brake System)																																
RX-8	North America Spec	13B-MSP Standard-Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	North America Spec	13B-MSP Standard-Power	IC(Instrument Cluster)																																
RX-8	North America Spec	13B-MSP Standard-Power	RCM(Restraint Control Module)																																
RX-8	North America Spec	13B-MSP Standard-Power	RKE(Remote Keyless Entry)																																
RX-8	North America Spec	13B-MSP Standard-Power	TCM(Transmission Control Module)																																
RX-8	North America Spec	13B-MSP Standard-Power	TPM(Tire Pressure Monitor)																																
RX-8	General	13B	SYSTEM SEARCH																																
RX-8	General	13B	PCM(Powertrain Control Module)																																
RX-8	General	13B	PATS(Passive anti theft system)-Beta																																
RX-8	General	13B	ABS(Anti-Lock Brake System)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
RX-8	General	13B	EPS(Electronic-Controlled Power Steering)																																
RX-8	General	13B	IC(Instrument Cluster)																																
RX-8	General	13B	RCM(Restraint Control Module)																																
RX-8	General	13B	RKE(Remote Keyless Entry)																																
RX-8	General	13B	TCM(Transmission Control Module)																																
RX-8	General	13B MSP High Power	SYSTEM SEARCH																																
RX-8	General	13B MSP High Power	PCM(Powertrain Control Module)																																
RX-8	General	13B MSP High Power	PATS(Passive anti theft system)-Beta																																
RX-8	General	13B MSP High Power	ABS(Anti-Lock Brake System)																																
RX-8	General	13B MSP High Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	General	13B MSP High Power	IC(Instrument Cluster)																																
RX-8	General	13B MSP High Power	RCM(Restraint Control Module)																																
RX-8	General	13B MSP High Power	RKE(Remote Keyless Entry)																																
RX-8	General	13B MSP High Power	TCM(Transmission Control Module)																																
RX-8	General	13B MSP Standard Power	SYSTEM SEARCH																																
RX-8	General	13B MSP Standard Power	PCM(Powertrain Control Module)																																
RX-8	General	13B MSP Standard Power	PATS(Passive anti theft system)-Beta																																
RX-8	General	13B MSP Standard Power	ABS(Anti-Lock Brake System)																																
RX-8	General	13B MSP Standard Power	EPS(Electronic-Controlled Power Steering)																																
RX-8	General	13B MSP Standard Power	IC(Instrument Cluster)																																
RX-8	General	13B MSP Standard Power	RCM(Restraint Control Module)																																
RX-8	General	13B MSP Standard Power	RKE(Remote Keyless Entry)																																
RX-8	General	13B MSP Standard Power	TCM(Transmission Control Module)																																
ESCAPETRIBUTE	Up to 2004	SYSTEM SEARCH																																	
ESCAPETRIBUTE	Up to 2004	PCM(PowerTrain Control Module)																																	
ESCAPETRIBUTE	Up to 2004	Immobilizer																																	
ESCAPETRIBUTE	Up to 2004	ABS(Anti-Lock Brake System)																																	
ESCAPETRIBUTE	Up to 2004	RCM(Restraint Control Module)																																	
ESCAPETRIBUTE	Up to 2004	GEM(Generic Electronic Module)																																	
ESCAPETRIBUTE	From 2004	SYSTEM SEARCH																																	
ESCAPETRIBUTE	From 2004	PCM(PowerTrain Control Module)										V		V	V																				
ESCAPETRIBUTE	From 2004	PATS(Passive anti theft system)																																	
ESCAPETRIBUTE	From 2004	ABS(Anti-Lock Brake System)																																	
ESCAPETRIBUTE	From 2004	RCM(Restraint Control Module)																																	
ESCAPETRIBUTE	From 2004	IC(Instrument Cluster)																																	
ESCAPETRIBUTE	From 2004	GEM(Generic Electronic Module)																																	
General(ALL Model)	16PIN CONNECTOR	SYSTEM SEARCH																																	
General(ALL Model)	16PIN CONNECTOR	PCM(PowerTrain Control Module)																																	
General(ALL Model)	16PIN CONNECTOR	PATS(Passive anti theft system)-Beta																																	
General(ALL Model)	16PIN CONNECTOR	TCM(Transmission Control Module)																																	
General(ALL Model)	16PIN CONNECTOR	ABS(Anti-Lock Brake System)																																	

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initializze the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
General(ALL Model)	16PIN CONNECTOR	RCM(Restraint Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	SYSTEM SEARCH																																	
General(ALL Model)	17PIN CONNECTOR	PCM(PowerTrain Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	TCM(Transmission Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	ABS(Anti-Lock Brake System)																																	
General(ALL Model)	17PIN CONNECTOR	RCM(Restraint Control Module)																																	
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	PCM(PowerTrain Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	TCM(Transmission Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	RCM(Restraint Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ABS(Anti-Lock Brake System)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ACCM(Air Conditioning Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	4WS(4 Wheel Steering)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ICCM(Intelligent Cruise Control Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	ABS(Anti-Lock Brake System)													V	V																		
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	EPS(Electronic-Controlled Power Steering)																	V	V	V	V												
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	IC(Instrument Cluster)																											V					
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RKE(Remote Keyless Entry)(WithSKE)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RKE(Remote Keyless Entry)(WIthout SKE)																																
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	VSM(Vehicle Security Module)																																
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	ASM																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	AT																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	PowerShift																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	ABS(Anti-Lock Brake System)												V	V												V						
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	ABS(Anti-Lock Brake System)												V	V												V						
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 (Low Power without DPF)	ASM																									V	V	V	V	V

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 (Low Power without DPF)	ALL																													V	V
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 + DPF (High Power with DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 3(High Power without DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	ABS(Anti-Lock Brake System)												V	V											V							
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 4(Low Power without DPF)																										V	V	V	V	V
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 4 + DPF (High Power with DPF)																												V	V	V
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 3(High Power without DPF)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	ABS(Anti-Lock Brake System)												V	V											V							
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	PCM(Powertrain Control Module)																												V	V	V
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	FACM(Fuel Additive Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	IC(Instrument Cluster)																									V						
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	1.6 Z6	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	ABS(Anti-Lock Brake System)													V	V											V							
BETA-ETC	MAZDA 3 EURO	1.6 Z6	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	GEM(Generic Electronic Module)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 3 EURO	1.6 Z6	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	ASM																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	AT																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	PowerShift																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	ABS(Anti-Lock Brake System)												V	V											V							
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	RCM(Restraint Control Module)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	ABS(Anti-Lock Brake System)												V	V											V							
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	ABS(Anti-Lock Brake System)												V	V											V							
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	FFH(Fuel Fired Coolant Heating Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	ASM																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	AT																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	PowerShift																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	ABS(Anti-Lock Brake System)												V	V											V							
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	ABS(Anti-Lock Brake System)												V	V											V							
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA GASOLINE ENGINE	PCM(Powertrain Control Module)																																	
BETA-ETC	MAZDA DIESEL ENGINE	PCM(Powertrain Control Module)																																	
BETA-ETC	MAZDA 2 ENGINE	PCM(Powertrain Control Module)										V	V	V	V																				
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	ABS(Anti-Lock Brake System)													V	V																		

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	ABS(Anti-Lock Brake System)													V	V																		
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	ABS(Anti-Lock Brake System)													V	V																		
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	SYSTEM SEARCH																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	ABS(Anti-Lock Brake System)													V	V																		
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	IC(Instrument Cluster)(Include PATS)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	RCM(Restraint Control Module)																																
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	SYSTEM SEARCH																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	PCM(Powertrain Control Module)										V	V	V	V																				
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	ABS(Anti-Lock Brake System)														V	V																		
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	EPS(Electronic-Controlled Power Steering)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	IC(Instrument Cluster)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	4x4(4x4 Control Module)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	RCM(Restraint Control Module)																																	
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	RKE(Remote Keyless Entry)																																	
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	SYSTEM SEARCH																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	PCM(Powertrain Control Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	ABS(Anti-Lock Brake System)													V	V																		
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	EPS(Electronic-Controlled Power Steering)																V	V	V	V													
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	IC(Instrument Cluster)																										V						
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	RCM(Restraint Control Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	RKE(Remote Keyless Entry)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	VSM(Vehicle Security Module)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	TCM(Transmission Control Module)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	EPS(Electronic-Controlled Power Steering)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	GEM(Generic Electronic Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	RCM(Restraint Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	RKE(Remote Keyless Entry)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	RKE(Remote Keyless Entry)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	TCM(Transmission Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	RCM(Restraint Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	MID(Multi-Information Display)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	RCM(Restraint Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	MID(Multi-Information Display)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	EATC(Electronic Automatic Temperature Control)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	ABS(Anti-Lock Brake System)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	RKE(Remote Keyless Entry)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	TCM(Transmission Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	SYSTEM SEARCH																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	PCM(Powertrain Control Module)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	IC(Instrument Cluster)																																
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 3 (North America/General)	SYSTEM SEARCH																																	
BETA-ETC	MAZDA 3 (North America/General)	PCM(Powertrain Control Module)																																	
BETA-ETC	MAZDA 3 (North America/General)	ABS(Anti-Lock Brake System)																																	
BETA-ETC	MAZDA 3 (North America/General)	IC(Instrument Cluster)																																	
BETA-ETC	MAZDA 3 (North America/General)	TPM(Tire Pressure Monitor)																																	
BETA-ETC	MAZDA 3 (China/General)	1.6L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 (China/General)	2.0L	RKE(Remote Keyless Entry)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	SYSTEM SEARCH																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	PCM(Powertrain Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	ABS(Anti-Lock Brake System)													V	V											V							
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	IC(Instrument Cluster)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	GEM(Generic Electronic Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RCM(Restraint Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	LPSDM(Left Power Sliding Door Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RPSDM(Right Power Sliding Door Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	TCM(Transmission Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RKE(Remote Keyless Entry)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	PCM(Powertrain Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	ABS(Anti-Lock Brake System)													V	V											V							
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	IC(Instrument Cluster)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	GEM(Generic Electronic Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RCM(Restraint Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	LPSDM(Left Power Sliding Door Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RPSDM(Right Power Sliding Door Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	TCM(Transmission Control Module)																																
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	ABS(Anti-Lock Brake System)													V	V											V							
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	TPM(Tire Pressure Monitor)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	PCM(Powertrain Control Module)	ALL																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	LHID(Left High Intensity Discharge Lamp)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	PCM(Powertrain Control Module)	ALL																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	PCM(Powertrain Control Module)	MT																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	GEM(Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	LHID(Left High Intensity Discharge Lamp)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RHID(Right High Intensity Discharge Lamp)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	LHID(Left High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	TCM(Transmission Control Module)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	SYSTEM SEARCH																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	PCM(Powertrain Control Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	ABS(Anti-Lock Brake System)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	GEM(Generic Electronic Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	IC(Instrument Cluster)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	LHID(Left High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RHID(Right High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RCM(Restraint Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RKE(Remote Keyless Entry)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	TCM(Transmission Control Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	SYSTEM SEARCH																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	PCM(Powertrain Control Module)	ALL																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	PCM(Powertrain Control Module)	MT																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	GEM(Generic Electronic Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	LHID(Left High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RHID(Right High Intensity Discharge Lamp)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	IC(Instrument Cluster)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RCM(Restraint Control Module)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RKE(Remote Keyless Entry)																																
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	IC(Instrument Cluster)						V	V																									
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	IC(Instrument Cluster)						V	V																									
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	IC(Instrument Cluster)						V	V																									

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	FFH(Fuel Fired Coolant Heating Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	IC(Instrument Cluster)						V	V																									
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	EATC(Electronic Automatic Temperature Control)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	IC(Instrument Cluster)						V	V																									
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RCM(Restraint Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RKE(Remote Keyless Entry)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RVM(Rear Vehicle Monitoring)-Beta Test																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	PCM(Powertrain Control Module)-ALL																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	TPM(Tire Pressure Monitor)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	SYSTEM SEARCH																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	TCM(Transmission Control Module)																																
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	TPM(Tire Pressure Monitor)																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	FFH(Fuel Fired Coolant Heating Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initialize the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	PCM(Powertrain Control Module)									V		V	V																				
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	PCM(Powertrain Control Module)									V		V	V																				
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	PCM(Powertrain Control Module)									V		V	V																				
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	RCM(Restraint Control Module)																																
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	GEM(Generic Electronic Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	HCM(Headlamp Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	ICCM(Intelligent Cruise Control Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	IC(Instrument Cluster)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	LTM(Liftgate/Trunk Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	RCM(Restraint Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	RKE(Remote Keyless Entry)																																
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	SYSTEM SEARCH																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	PCM(Powertrain Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	ABS(Anti-Lock Brake System)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	GEM(Generic Electronic Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	HCM(Headlamp Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	ICCM(Intelligent Cruise Control Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	IC(Instrument Cluster)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LTM(Liftgate/Trunk Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RCM(Restraint Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RKE(Remote Keyless Entry)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	TCM(Transmission Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LCM(Lighting Control Module)-Beta Test																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	4x4(4x4 Control Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LPSDM(Left Power Sliding Door Module)																																
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RPSDM(Right Power Sliding Door Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Transmission Learning	ABS/DSC Sensor Initialzation	ABS Baking Service Bleed	Wheel Unit ID Registration	Monitor Wheel Unit ID Registration	Module installation	MAF Sensor/TP Sensor Dynamic Test	Variable Cam Timing Test	Air Conditioning Test	EGR System Flow Test	Brake Fluid Pressure Sensor Initialize	Lateral Acceleration Sensor Initialize	Brake Fluid Pressure Sensor	Yaw Rate Sensor	Calibration After Parts Removal or Replacement	Restoration Procedure for DTC_C1B00_95	Restoration Procedure for DTC_C1B00_54	EPS Installation	Reset the EGR valve learned values	Reset the DPF learned values	Reset the DPF differential pressure sensor learned values	Reset the air conditioning compressor learned values	Initializre the Exhaust Gas Related Component	ABS Module Installation	Warning Lamps/Chimes	Injector Correction Factors	Static Regeneration	Reset Particulate Filter Learned Values	Reset EGR Valve Position Offset	Reset EGR Throttle Valve Position
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	SYSTEM SEARCH																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	PCM(Powertrain Control Module)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	ABS(Anti-Lock Brake System)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	IC(Instrument Cluster)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	TCM(Transmission Control Module)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	SYSTEM SEARCH																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	2005~																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	~2005																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	ABS(Anti-Lock Brake System)																																
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	TCM(Transmission Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	SYSTEM SEARCH																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	PCM(Powertrain Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	ABS(Anti-Lock Brake System)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	RCM(Restraint Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	TCM(Transmission Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	SYSTEM SEARCH																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	PCM(Powertrain Control Module)																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	ABS(Anti-Lock Brake System)																																
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	TCM(Transmission Control Module)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	SYSTEM SEARCH																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	PCM(Powertrain Control Module)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	ABS(Anti-Lock Brake System)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	GEM(Generic Electronic Module)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	IC(Instrument Cluster)																																
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	RCM(Restraint Control Module)																																
BETA-ETC	TITAN DASH	2.0L RF_T	SYSTEM SEARCH																																
BETA-ETC	TITAN DASH	2.0L RF_T	PCM(Powertrain Control Module)																																
BETA-ETC	TITAN DASH	2.0L RF_T	TCM(Transmission Control Module)																																
BETA-ETC	PATS(Passive anti theft system)																																		
BETA-ETC	Vehicle Log Capture																																		

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
Incode Calculator	Incode Calculator	~2010.05																																
Service Manual	Reset the Oil Change Indicator(G-scan Support)																																	
Service Manual	Oil Light Reset / Service Light Reset(Manual)																																	
Service Manual	Throttle Body Learning																																	
BIANTE	2.0L LF	SYSTEM SEARCH																																
BIANTE	2.0L LF	PCM(Powertrain Control Module)																																
BIANTE	2.0L LF	ABS(Anti-Lock Brake System)																																
BIANTE	2.0L LF	EATC(Electronic Automatic Temperature Control)																																
BIANTE	2.0L LF	EPS(Electronic-Controlled Power Steering)																																
BIANTE	2.0L LF	GEM(Generic Electronic Module)																																
BIANTE	2.0L LF	IC(Instrument Cluster)																																
BIANTE	2.0L LF	LPSDM(Left Power Sliding Door Module)																																
BIANTE	2.0L LF	RCM(Restraint Control Module)																																
BIANTE	2.0L LF	RKE(Remote Keyless Entry)																																
BIANTE	2.0L LF	RPSDM(Right Power Sliding Door Module)																																
BIANTE	2.0L LF	TCM(Transmission Control Module)																																
BIANTE	2.3L L3	SYSTEM SEARCH																																
BIANTE	2.3L L3	PCM(Powertrain Control Module)																																
BIANTE	2.3L L3	ABS(Anti-Lock Brake System)																																
BIANTE	2.3L L3	EATC(Electronic Automatic Temperature Control)																																
BIANTE	2.3L L3	EPS(Electronic-Controlled Power Steering)																																
BIANTE	2.3L L3	GEM(Generic Electronic Module)																																
BIANTE	2.3L L3	IC(Instrument Cluster)																																
BIANTE	2.3L L3	LPSDM(Left Power Sliding Door Module)																																
BIANTE	2.3L L3	RCM(Restraint Control Module)																																
BIANTE	2.3L L3	RKE(Remote Keyless Entry)																																
BIANTE	2.3L L3	RPSDM(Right Power Sliding Door Module)																																
BIANTE	2.3L L3	TCM(Transmission Control Module)																																
BONGOBRAWNYSPECTRON	2.0L RF_T	SYSTEM SEARCH																																
BONGOBRAWNYSPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	2005~																															
BONGOBRAWNYSPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	~2005																															
BONGOBRAWNYSPECTRON	2.0L RF_T	ABS(Anti-Lock Brake System)																																
BONGOBRAWNYSPECTRON	2.0L RF_T	TCM(Transmission Control Module)																																
BT-50(RANGER)	2.2 Diesel	SYSTEM SEARCH																																
BT-50(RANGER)	2.2 Diesel	PCM(PowerTrain Control Module)																																
BT-50(RANGER)	2.2 Diesel	ABS(Anti-Lock Brake System)																																
BT-50(RANGER)	2.2 Diesel	ACM(Audio Control Module)																																
BT-50(RANGER)	2.2 Diesel	BCMii(Body Control Module)																																
BT-50(RANGER)	2.2 Diesel	DDM(Drivers Door Module)																																
BT-50(RANGER)	2.2 Diesel	FCDIM(Front Control/Display Interface Module)																																
BT-50(RANGER)	2.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BT-50(RANGER)	2.2 Diesel	IPC(Instrument Panel Control Module)																																
BT-50(RANGER)	2.2 Diesel	PAM(Parking Aid Module)																																
BT-50(RANGER)	2.2 Diesel	PDM(Passengers Door Module)																																
BT-50(RANGER)	2.2 Diesel	RCM(Restraint Control Module)																																
BT-50(RANGER)	2.2 Diesel	SRM(Speech Recognition Module)																																
BT-50(RANGER)	2.2 Diesel	TBM(Tracking And Blocking Module)																																
BT-50(RANGER)	2.2 Diesel	TCM(Transmission Control Module)																																
BT-50(RANGER)	2.2 Diesel	TRM(Trailer Module)																																
BT-50(RANGER)	2.2 Diesel	PATS(Passive anti theft system)																																
BT-50(RANGER)	2.5 Diesel(WL-CD)	SYSTEM SEARCH																																
BT-50(RANGER)	2.5 Diesel(WL-CD)	PCM(PowerTrain Control Module)																																
BT-50(RANGER)	2.5 Diesel(WL-CD)	TCM(Transmission Control Module)																																
BT-50(RANGER)	2.5 Diesel(WL-CD)	ABS(Anti-Lock Brake System)																																
BT-50(RANGER)	2.5 Diesel(WL-CD)	RCM(Restraint Control Module)																																
BT-50(RANGER)	2.5 Diesel(WL-CD)	PATS(Passive anti theft system)																																
BT-50(RANGER)	3.0 Diesel(WE-CD)	SYSTEM SEARCH																																
BT-50(RANGER)	3.0 Diesel(WE-CD)	PCM(PowerTrain Control Module)																																
BT-50(RANGER)	3.0 Diesel(WE-CD)	TCM(Transmission Control Module)																																
BT-50(RANGER)	3.0 Diesel(WE-CD)	ABS(Anti-Lock Brake System)																																
BT-50(RANGER)	3.0 Diesel(WE-CD)	RCM(Restraint Control Module)																																
BT-50(RANGER)	3.0 Diesel(WE-CD)	PATS(Passive anti theft system)																																
BT-50(RANGER)	3.2 Diesel	SYSTEM SEARCH																																
BT-50(RANGER)	3.2 Diesel	PCM(PowerTrain Control Module)																																
BT-50(RANGER)	3.2 Diesel	ABS(Anti-Lock Brake System)																																
BT-50(RANGER)	3.2 Diesel	ACM(Audio Control Module)																																
BT-50(RANGER)	3.2 Diesel	BCMii(Body Control Module)																																
BT-50(RANGER)	3.2 Diesel	DDM(Drivers Door Module)																																
BT-50(RANGER)	3.2 Diesel	FCDIM(Front Control/Display Interface Module)																																
BT-50(RANGER)	3.2 Diesel	HVAC(Heating Ventilation Air Conditioning)																																
BT-50(RANGER)	3.2 Diesel	IPC(Instrument Panel Control Module)																																
BT-50(RANGER)	3.2 Diesel	PAM(Parking Aid Module)																																
BT-50(RANGER)	3.2 Diesel	PDM(Passengers Door Module)																																
BT-50(RANGER)	3.2 Diesel	RCM(Restraint Control Module)																																
BT-50(RANGER)	3.2 Diesel	SRM(Speech Recognition Module)																																
BT-50(RANGER)	3.2 Diesel	TBM(Tracking And Blocking Module)																																
BT-50(RANGER)	3.2 Diesel	TCM(Transmission Control Module)																																
BT-50(RANGER)	3.2 Diesel	TRM(Trailer Module)																																
BT-50(RANGER)	3.2 Diesel	PATS(Passive anti theft system)																																
BT-50(RANGER)	2.3 Gasoline	PCM(Powertrain Control Module)																																
BT-50(RANGER)	2.3 Gasoline	ABS(Anti-Lock Brake System)																																
BT-50(RANGER)	2.3 Gasoline	GEM(Generic Electronic Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BT-50(RANGER)	2.3 Gasoline	IC(Instrument Cluster)																																
BT-50(RANGER)	2.3 Gasoline	OCSM(Occupant Classification System Module)																																
BT-50(RANGER)	2.3 Gasoline	4x4(4x4 Control Module)																																
BT-50(RANGER)	2.3 Gasoline	RCM(Restraint Control Module)																																
BT-50(RANGER)	2.3 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																
BT-50(RANGER)	2.3 Gasoline	TCM(Transmission Control Module)																																
BT-50(RANGER)	2.5 Gasoline	SYSTEM SEARCH																																
BT-50(RANGER)	2.5 Gasoline	PCM(PowerTrain Control Module)																																
BT-50(RANGER)	2.5 Gasoline	ABS(Anti-Lock Brake System)																																
BT-50(RANGER)	2.5 Gasoline	ACM(Audio Control Module)																																
BT-50(RANGER)	2.5 Gasoline	BCMii(Body Control Module)																																
BT-50(RANGER)	2.5 Gasoline	DDM(Drivers Door Module)																																
BT-50(RANGER)	2.5 Gasoline	FCDIM(Front Control/Display Interface Module)																																
BT-50(RANGER)	2.5 Gasoline	HVAC(Heating Ventilation Air Conditioning)																																
BT-50(RANGER)	2.5 Gasoline	IPC(Instrument Panel Control Module)																																
BT-50(RANGER)	2.5 Gasoline	PAM(Parking Aid Module)																																
BT-50(RANGER)	2.5 Gasoline	PDM(Passengers Door Module)																																
BT-50(RANGER)	2.5 Gasoline	RCM(Restraint Control Module)																																
BT-50(RANGER)	2.5 Gasoline	SRM(Speech Recognition Module)																																
BT-50(RANGER)	2.5 Gasoline	TBM(Tracking And Blocking Module)																																
BT-50(RANGER)	2.5 Gasoline	TCM(Transmission Control Module)																																
BT-50(RANGER)	2.5 Gasoline	TRM(Trailer Module)																																
BT-50(RANGER)	2.5 Gasoline	PATS(Passive anti theft system)																																
BT-50(RANGER)	3.0 Gasoline	SYSTEM SEARCH																																
BT-50(RANGER)	3.0 Gasoline	PCM(Powertrain Control Module)																																
BT-50(RANGER)	3.0 Gasoline	ABS(Anti-Lock Brake System)																																
BT-50(RANGER)	3.0 Gasoline	GEM(Generic Electronic Module)																																
BT-50(RANGER)	3.0 Gasoline	IC(Instrument Cluster)																																
BT-50(RANGER)	3.0 Gasoline	OCSM(Occupant Classification System Module)																																
BT-50(RANGER)	3.0 Gasoline	4x4(4x4 Control Module)																																
BT-50(RANGER)	3.0 Gasoline	RCM(Restraint Control Module)																																
BT-50(RANGER)	3.0 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																
BT-50(RANGER)	3.0 Gasoline	TCM(Transmission Control Module)																																
BT-50(RANGER)	4.0 Gasoline	SYSTEM SEARCH																																
BT-50(RANGER)	4.0 Gasoline	PCM(Powertrain Control Module)																																
BT-50(RANGER)	4.0 Gasoline	ABS(Anti-Lock Brake System)																																
BT-50(RANGER)	4.0 Gasoline	GEM/SJB(Generic Electronic Module/Smart Junction Box)																																
BT-50(RANGER)	4.0 Gasoline	IC(Instrument Cluster)																																
BT-50(RANGER)	4.0 Gasoline	OCSM(Occupant Classification System Module)																																
BT-50(RANGER)	4.0 Gasoline	4x4(4x4 Control Module)																																
BT-50(RANGER)	4.0 Gasoline	RCM(Restraint Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BT-50(RANGER)	4.0 Gasoline	SDARS(Satellite Digital Audio Receiver System)																																
BT-50(RANGER)	4.0 Gasoline	TCM(Transmission Control Module)																																
CX-3	1.5L S5	SYSTEM SEARCH																																
CX-3	1.5L S5	PCM(Powertrain Control Module)																																
CX-3	1.5L S5	TCM(Transmission Control Module)																																
CX-3	1.5L S5	4x4(4x4 Control Module)																																
CX-3	1.5L S5	ABS(Anti-Lock Brake System)																																
CX-3	1.5L S5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																
CX-3	1.5L S5	EATC(Electronic Automatic Temperature Control)																																
CX-3	1.5L S5	EPS(Electronic-Controlled Power Steering)																																
CX-3	1.5L S5	ESU(Electric Supply Unit)																																
CX-3	1.5L S5	IC(Instrument Cluster)																																
CX-3	1.5L S5	RCM(Restraint Control Module)																																
CX-3	1.5L S5	BSM(Blind Spot Monitoring)																																
CX-3	1.5L S5	BCM(Body Control Module)																																
CX-3	1.5L S5	CMU(Connectivity Master Unit)																																
CX-3	1.5L S5	FSC(Forward Sensing Camera)																																
CX-3	1.5L S5	SSU(Smart Start Unit)																																
CX-3	1.5L S5	SCBS(Smart City Brake Support)																																
CX-3	1.5L S5	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																
CX-3	2.0L PE	SYSTEM SEARCH																																
CX-3	2.0L PE	PCM(Powertrain Control Module)																																
CX-3	2.0L PE	TCM(Transmission Control Module)																																
CX-3	2.0L PE	4x4(4x4 Control Module)																																
CX-3	2.0L PE	ABS(Anti-Lock Brake System)																																
CX-3	2.0L PE	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																
CX-3	2.0L PE	EATC(Electronic Automatic Temperature Control)																																
CX-3	2.0L PE	EPS(Electronic-Controlled Power Steering)																																
CX-3	2.0L PE	ESU(Electric Supply Unit)																																
CX-3	2.0L PE	IC(Instrument Cluster)																																
CX-3	2.0L PE	RCM(Restraint Control Module)																																
CX-3	2.0L PE	BSM(Blind Spot Monitoring)																																
CX-3	2.0L PE	BCM(Body Control Module)																																
CX-3	2.0L PE	CMU(Connectivity Master Unit)																																
CX-3	2.0L PE	FSC(Forward Sensing Camera)																																
CX-3	2.0L PE	SSU(Smart Start Unit)																																
CX-3	2.0L PE	SCBS(Smart City Brake Support)																																
CX-3	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																
CX-5	2.0L PE	SYSTEM SEARCH																																
CX-5	2.0L PE	PCM(Powertrain Control Module)																																
CX-5	2.0L PE	TCM(Transmission Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
CX-5	2.0L PE	4x4(4x4 Control Module)																																
CX-5	2.0L PE	ABS(Anti-Lock Brake System)																																
CX-5	2.0L PE	ACU(Audio Control Unit)																																
CX-5	2.0L PE	EATC(Electronic Automatic Temperature Control)																																
CX-5	2.0L PE	AM(Amplifier Module)																																
CX-5	2.0L PE	AFS(Adaptive Front Lighting System)																																
CX-5	2.0L PE	DSM(Drivers Seat Module)																																
CX-5	2.0L PE	DCDC(DC to DC Converter Control Module)																																
CX-5	2.0L PE	FSC(Forward Sensing Camera)																																
CX-5	2.0L PE	SCBS(Smart City Brake Support)																																
CX-5	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																
CX-5	2.0L PE	EPS(Electronic-Controlled Power Steering)																																
CX-5	2.0L PE	IC(Instrument Cluster)																																
CX-5	2.0L PE	RVM(Rear Vehicle Monitoring)																																
CX-5	2.0L PE	RCM(Restraint Control Module)																																
CX-5	2.0L PE	SSU(Smart Start Unit)																																
CX-5	2.0L PE	BSM(Blind Spot Monitoring)																																
CX-5	2.0L PE	F_BCM(Front Body Control Module)																																
CX-5	2.0L PE	R_BCM(Rear Body Control Module)																																
CX-5	2.2L SH	SYSTEM SEARCH																																
CX-5	2.2L SH	PCM(Powertrain Control Module)																																
CX-5	2.2L SH	TCM(Transmission Control Module)																																
CX-5	2.2L SH	4x4(4x4 Control Module)																																
CX-5	2.2L SH	ABS(Anti-Lock Brake System)																																
CX-5	2.2L SH	ACU(Audio Control Unit)																																
CX-5	2.2L SH	CMU(Connectivity Master Unit)																																
CX-5	2.2L SH	EATC(Electronic Automatic Temperature Control)																																
CX-5	2.2L SH	AM(Amplifier Module)																																
CX-5	2.2L SH	AFS(Adaptive Front Lighting System)																																
CX-5	2.2L SH	DSM(Drivers Seat Module)																																
CX-5	2.2L SH	DCDC(DC to DC Converter Control Module)																																
CX-5	2.2L SH	FSC(Forward Sensing Camera)																																
CX-5	2.2L SH	SCBS(Smart City Brake Support)																																
CX-5	2.2L SH	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																
CX-5	2.2L SH	EPB(Electonic Parking Brake)																																
CX-5	2.2L SH	EPS(Electronic-Controlled Power Steering)																																
CX-5	2.2L SH	IC(Instrument Cluster)																																
CX-5	2.2L SH	RVM(Rear Vehicle Monitoring)																																
CX-5	2.2L SH	RCM(Restraint Control Module)																																
CX-5	2.2L SH	SSU(Smart Start Unit)																																
CX-5	2.2L SH	BSM(Blind Spot Monitoring)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
CX-5	2.2L SH	F_BCM(Front Body Control Module)																																
CX-5	2.2L SH	R_BCM(Rear Body Control Module)																																
CX-5	2.5L PY	SYSTEM SEARCH																																
CX-5	2.5L PY	PCM(Powertrain Control Module)																																
CX-5	2.5L PY	TCM(Transmission Control Module)																																
CX-5	2.5L PY	4x4(4x4 Control Module)																																
CX-5	2.5L PY	ABS(Anti-Lock Brake System)																																
CX-5	2.5L PY	AM(Amplifier Module)																																
CX-5	2.5L PY	DSM(Drivers Seat Module)																																
CX-5	2.5L PY	EATC(Electronic Automatic Temperature Control)																																
CX-5	2.5L PY	EPB(Electonic Parking Brake)																																
CX-5	2.5L PY	EPS(Electronic-Controlled Power Steering)																																
CX-5	2.5L PY	IC(Instrument Cluster)																																
CX-5	2.5L PY	RCM(Restraint Control Module)																																
CX-5	2.5L PY	AFS(Adaptive Front Lighting System)																																
CX-5	2.5L PY	FSC(Forward Sensing Camera)																																
CX-5	2.5L PY	SSU(Smart Start Unit)																																
CX-5	2.5L PY	BSM(Blind Spot Monitoring)-JAPAN																																
CX-5	2.5L PY	BSML(Blind Spot Monitoring Left)																																
CX-5	2.5L PY	BSMR(Blind Spot Monitoring Right)																																
CX-5	2.5L PY	F_BCM(Front Body Control Module)																																
CX-5	2.5L PY	R_BCM(Rear Body Control Module)																																
CX-5	2.5L PY	SCBS(Smart City Brake Support)																																
CX-5	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																
CX-5	2.5L PY	ACU(Audio Control Unit)																																
CX-5	2.5L PY	CMU(Connectivity Master Unit)																																
CX-7	2.2L R2_T (Diesel)	SYSTEM SEARCH																																
CX-7	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)																																
CX-7	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																																
CX-7	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																
CX-7	2.2L R2_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																
CX-7	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																
CX-7	2.2L R2_T (Diesel)	GEM(Generic Electronic Module)																																
CX-7	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																
CX-7	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																																
CX-7	2.2L R2_T (Diesel)	MID(Multi-Information Display)																																
CX-7	2.2L R2_T (Diesel)	SCR CU(Selective Catalytic Reduction)																																
CX-7	2.2L R2_T (Diesel)	RKE(Remote Keyless Entry)																																
CX-7	2.2L R2_T (Diesel)	RVM(Rear Vehicle Monitoring)																																
CX-7	2.2L R2_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																
CX-7	2.3L L3_T	SYSTEM SEARCH																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
CX-7	2.3L L3_T	PCM(Powertrain Control Module)																																
CX-7	2.3L L3_T	PATS(Passive anti theft system)-Beta																																
CX-7	2.3L L3_T	ABS(Anti-Lock Brake System)																																
CX-7	2.3L L3_T	EATC(Electronic Automatic Temperature Control)																																
CX-7	2.3L L3_T	AM(Amplifier Module)																																
CX-7	2.3L L3_T	GEM(Generic Electronic Module)																																
CX-7	2.3L L3_T	IC(Instrument Cluster)																																
CX-7	2.3L L3_T	RCM(Restraint Control Module)																																
CX-7	2.3L L3_T	TCM(Transmission Control Module)																																
CX-7	2.3L L3_T	ACU(Audio Control Unit)																																
CX-7	2.3L L3_T	4*4(4*4 Control Module)																																
CX-7	2.3L L3_T	MID(Multi-Information Display)																																
CX-7	2.3L L3_T	RKE(Remote Keyless Entry)																																
CX-7	2.3L L3_T	LCM(Lighting Control Module)																																
CX-7	2.3L L3_T	RVM(Rear Vehicle Monitoring)																																
CX-7	2.5L L5	SYSTEM SEARCH																																
CX-7	2.5L L5	PCM(Powertrain Control Module)																																
CX-7	2.5L L5	PATS(Passive anti theft system)-Beta																																
CX-7	2.5L L5	TCM(Transmission Control Module)																																
CX-7	2.5L L5	ABS(Anti-Lock Brake System)																																
CX-7	2.5L L5	RCM(Restraint Control Module)																																
CX-7	2.5L L5	GEM(Generic Electronic Module)																																
CX-7	2.5L L5	IC(Instrument Cluster)																																
CX-7	2.5L L5	MID(Multi-Information Display)-Beta Test																																
CX-7	2.5L L5	EATC(Electronic Automatic Temperature Control)																																
CX-7	2.5L L5	ACU(Audio Control Unit)																																
CX-7	2.5L L5	ICCM(Intelligent Cruise Control Module)																																
CX-7	2.5L L5	RKE(Remote Keyless Entry)																																
CX-7	2.5L L5	RVM(Rear Vehicle Monitoring)																																
CX-7	2.5L L5	LCM(Lighting Control Module)																																
CX-9	3.7L CA	SYSTEM SEARCH																																
CX-9	3.7L CA	PCM(Powertrain Control Module)																																
CX-9	3.7L CA	PATS(Passive anti theft system)-Beta																																
CX-9	3.7L CA	ABS(Anti-Lock Brake System)																																
CX-9	3.7L CA	4WD(Four Wheel Drive)-Beta Test																																
CX-9	3.7L CA	DSM(Drivers Seat Module)																																
CX-9	3.7L CA	GEM(Generic Electronic Module)																																
CX-9	3.7L CA	IC(Instrument Cluster) - Without Tire Pressure Monitor																																
CX-9	3.7L CA	IC(Instrument Cluster) - With Tire Pressure Monitor-Beta Test																																
CX-9	3.7L CA	LCM(Lighting Control Module)-Beta Test																																
CX-9	3.7L CA	LTM(Liftgate/Trunk Module)-Beta Test																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
CX-9	3.7L CA	RCM(Restraint Control Module) - Except USA																																
CX-9	3.7L CA	RCM(Restraint Control Module) - USA-Beta Test																																
CX-9	3.7L CA	RKE(Remote Keyless Entry)-Beta Test																																
CX-9	3.7L CA	TCM(Transmission Control Module)																																
CX-9	3.7L CA	BSML(Blind Spot Monitoring Left)-Beta Test																																
CX-9	3.7L CA	BSMR(Blind Spot Monitoring Right)-Beta Test																																
CX-9	3.5L CY-Beta Test	SYSTEM SEARCH																																
CX-9	3.5L CY-Beta Test	PCM(Powertrain Control Module)																																
CX-9	3.5L CY-Beta Test	PATS(Passive anti theft system)-Beta																																
CX-9	3.5L CY-Beta Test	ABS(Anti-Lock Brake System)																																
CX-9	3.5L CY-Beta Test	4WD(Four Wheel Drive)																																
CX-9	3.5L CY-Beta Test	GEM(Generic Electronic Module)																																
CX-9	3.5L CY-Beta Test	IC(Instrument Cluster) - Without Tire Pressure Monitor																																
CX-9	3.5L CY-Beta Test	IC(Instrument Cluster) - With Tire Pressure Monitor																																
CX-9	3.5L CY-Beta Test	LTM(Liftgate/Trunk Module)																																
CX-9	3.5L CY-Beta Test	RCM(Restraint Control Module) - USA																																
CX-9	3.5L CY-Beta Test	RKE(Remote Keyless Entry)																																
CX-9	3.5L CY-Beta Test	TCM(Transmission Control Module)																																
DEMIOVERISAMAZDA2	1.3L ZJ	SYSTEM SEARCH																																
DEMIOVERISAMAZDA2	1.3L ZJ	PCM(Powertrain Control Module)																																
DEMIOVERISAMAZDA2	1.3L ZJ	PATS(Passive anti theft system)-Beta																																
DEMIOVERISAMAZDA2	1.3L ZJ	ABS(Anti-Lock Brake System)																																
DEMIOVERISAMAZDA2	1.3L ZJ	BCM/GEM(Body Control Module/Generic Electronic Module)																																
DEMIOVERISAMAZDA2	1.3L ZJ	IC(Instrument Cluster)																																
DEMIOVERISAMAZDA2	1.3L ZJ	RCM(Restraint Control Module)																																
DEMIOVERISAMAZDA2	1.3L ZJ	EPS(Electronic-Controlled Power Steering)																																
DEMIOVERISAMAZDA2	1.3L ZJ	RKE(Remote Keyless Entry)																																
DEMIOVERISAMAZDA2	1.3L P3	SYSTEM SEARCH																																
DEMIOVERISAMAZDA2	1.3L P3	PCM(Powertrain Control Module)																																
DEMIOVERISAMAZDA2	1.3L P3	TCM(Transmission Control Module)																																
DEMIOVERISAMAZDA2	1.3L P3	ABS(Anti-Lock Brake System)																																
DEMIOVERISAMAZDA2	1.3L P3	BCM(Body Control Module)																																
DEMIOVERISAMAZDA2	1.3L P3	EATC(Electronic Automatic Temperature Control)																																
DEMIOVERISAMAZDA2	1.3L P3	EPS(Electronic-Controlled Power Steering)																																
DEMIOVERISAMAZDA2	1.3L P3	FSC(Forward Sensing Camera)																																
DEMIOVERISAMAZDA2	1.3L P3	IC(Instrument Cluster)																																
DEMIOVERISAMAZDA2	1.3L P3	RCM(Restraint Control Module)																																
DEMIOVERISAMAZDA2	1.3L P3	SSU(Smart Start Unit)																																
DEMIOVERISAMAZDA2	1.3L P3	SCBS(Smart City Brake Support)																																
DEMIOVERISAMAZDA2	1.3L P3	ALM(Auto Leveling Module)																																
DEMIOVERISAMAZDA2	1.3L P3	BSM(Blind Spot Monitoring)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
DEMIOVERISAMAZDA2	1.3L P3	CMU(Connectivity Master Unit)																																
DEMIOVERISAMAZDA2	1.3L P3	ESU(Electric Supply Unit)																																
DEMIOVERISAMAZDA2	1.5L ZY	SYSTEM SEARCH																																
DEMIOVERISAMAZDA2	1.5L ZY	PCM(Powertrain Control Module)																																
DEMIOVERISAMAZDA2	1.5L ZY	PATS(Passive anti theft system)-Beta																																
DEMIOVERISAMAZDA2	1.5L ZY	ABS(Anti-Lock Brake System)																																
DEMIOVERISAMAZDA2	1.5L ZY	IC(Instrument Cluster)																																
DEMIOVERISAMAZDA2	1.5L ZY	EPS(Electronic-Controlled Power Steering)																																
DEMIOVERISAMAZDA2	1.5L ZY	BCM/GEM(Body Control Module/Generic Electronic Module)																																
DEMIOVERISAMAZDA2	1.5L ZY	RCM(Restraint Control Module)																																
DEMIOVERISAMAZDA2	1.5L ZY	RKE(Remote Keyless Entry)	With SKE																															
DEMIOVERISAMAZDA2	1.5L ZY	RKE(Remote Keyless Entry)	Without SKE																															
DEMIOVERISAMAZDA2	1.5L ZY	VSM(Vehicle Security Module)																																
DEMIOVERISAMAZDA2	1.5L P5	SYSTEM SEARCH																																
DEMIOVERISAMAZDA2	1.5L P5	PCM(Powertrain Control Module)																																
DEMIOVERISAMAZDA2	1.5L P5	ABS(Anti-Lock Brake System)																																
DEMIOVERISAMAZDA2	1.5L P5	EATC(Electronic Automatic Temperature Control)																																
DEMIOVERISAMAZDA2	1.5L P5	EPS(Electronic-Controlled Power Steering)																																
DEMIOVERISAMAZDA2	1.5L P5	IC(Instrument Cluster)																																
DEMIOVERISAMAZDA2	1.5L P5	RCM(Restraint Control Module)																																
DEMIOVERISAMAZDA2	1.5L P5	TCM(Transmission Control Module)																																
DEMIOVERISAMAZDA2	1.5L P5	BSM(Blind Spot Monitoring)																																
DEMIOVERISAMAZDA2	1.5L P5	BCM(Body Control Module)																																
DEMIOVERISAMAZDA2	1.5L P5	FSC(Forward Sensing Camera)																																
DEMIOVERISAMAZDA2	1.5L P5	SSU(Smart Start Unit)																																
DEMIOVERISAMAZDA2	1.5L P5	SCBS(Smart City Brake Support)																																
DEMIOVERISAMAZDA2	1.5L P5	ALM(Auto Leveling Module)																																
DEMIOVERISAMAZDA2	1.5L P5	CMU(Connectivity Master Unit)																																
DEMIOVERISAMAZDA2	1.5L P5	ESU(Electric Supply Unit)																																
DEMIOVERISAMAZDA2	1.5L S5	SYSTEM SEARCH																																
DEMIOVERISAMAZDA2	1.5L S5	PCM(Powertrain Control Module)																																
DEMIOVERISAMAZDA2	1.5L S5	TCM(Transmission Control Module)																																
DEMIOVERISAMAZDA2	1.5L S5	4x4(4x4 Control Module)																																
DEMIOVERISAMAZDA2	1.5L S5	ABS(Anti-Lock Brake System)																																
DEMIOVERISAMAZDA2	1.5L S5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																																
DEMIOVERISAMAZDA2	1.5L S5	EATC(Electronic Automatic Temperature Control)																																
DEMIOVERISAMAZDA2	1.5L S5	EPS(Electronic-Controlled Power Steering)																																
DEMIOVERISAMAZDA2	1.5L S5	ESU(Electric Supply Unit)																																
DEMIOVERISAMAZDA2	1.5L S5	IC(Instrument Cluster)																																
DEMIOVERISAMAZDA2	1.5L S5	RCM(Restraint Control Module)																																
DEMIOVERISAMAZDA2	1.5L S5	BSM(Blind Spot Monitoring)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
DEMIOVERISAMAZDA2	1.5L S5	BCM(Body Control Module)																																
DEMIOVERISAMAZDA2	1.5L S5	CMU(Connectivity Master Unit)																																
DEMIOVERISAMAZDA2	1.5L S5	FSC(Forward Sensing Camera)																																
DEMIOVERISAMAZDA2	1.5L S5	SSU(Smart Start Unit)																																
DEMIOVERISAMAZDA2	1.5L S5	SCBS(Smart City Brake Support)																																
DEMIOVERISAMAZDA2	1.5L S5	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	SYSTEM SEARCH																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	PCM(Powertrain Control Module)																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	PATS(Passive anti theft system)-Beta																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	ABS(Anti-Lock Brake System)																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	IC(Instrument Cluster)																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	EPS(Electronic-Controlled Power Steering)																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	BCM/GEM(Body Control Module/Generic Electronic Module)																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RCM(Restraint Control Module)																																
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RKE(Remote Keyless Entry)	With SKE																															
DEMIOVERISAMAZDA2	1.6L Y6-Beta	RKE(Remote Keyless Entry)	Without SKE																															
DEMIOVERISAMAZDA2	1.6L Y6-Beta	VSM(Vehicle Security Module)																																
AXELAMAZDA3	1.5L ZY	SYSTEM SEARCH																																
AXELAMAZDA3	1.5L ZY	PCM(Powertrain Control Module)																																
AXELAMAZDA3	1.5L ZY	ABS(Anti-Lock Brake System)																																
AXELAMAZDA3	1.5L ZY	EPS(Electronic-Controlled Power Steering)																																
AXELAMAZDA3	1.5L ZY	RCM(Restraint Control Module)																																
AXELAMAZDA3	1.5L ZY	IC(Instrument Cluster)																																
AXELAMAZDA3	1.5L ZY	GEM(Generic Electronic Module)																																
AXELAMAZDA3	1.5L ZY	PATS(Passive anti theft system)-Beta																																
AXELAMAZDA3	1.6L Y6	SYSTEM SEARCH																																
AXELAMAZDA3	1.6L Y6	PCM(Powertrain Control Module)				V	V																											
AXELAMAZDA3	1.6L Y6	ABS(Anti-Lock Brake System)																																
AXELAMAZDA3	1.6L Y6	BCM/GEM(Body Control Module/Generic Electronic Module)																																
AXELAMAZDA3	1.6L Y6	EATC(Electronic Automatic Temperature Control)																																
AXELAMAZDA3	1.6L Y6	EPS(Electronic-Controlled Power Steering)																																
AXELAMAZDA3	1.6L Y6	FACM(Fuel Additive Control Module)						V	V	V																								
AXELAMAZDA3	1.6L Y6	IC(Instrument Cluster)																																
AXELAMAZDA3	1.6L Y6	RCM(Restraint Control Module)																																
AXELAMAZDA3	1.6L Y6	RKE(Remote Keyless Entry)																																
AXELAMAZDA3	1.6L Y6	BSML(Blind Spot Monitoring Left)																																
AXELAMAZDA3	1.6L Y6	BSMR(Blind Spot Monitoring Right)																																
AXELAMAZDA3	1.6L Y6	AFS(Adaptive Front Lighting System)																																
AXELAMAZDA3	1.6L Y6	MID(Multi-Information Display)																																
AXELAMAZDA3	1.6L Y6	ACU(Audio Control Unit)																																
AXELAMAZDA3	1.6L Y6	PATS(Passive anti theft system)-Beta																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
AXELAMAZDA3	1.6L Z6	SYSTEM SEARCH																																
AXELAMAZDA3	1.6L Z6	PCM(Powertrain Control Module)																																
AXELAMAZDA3	1.6L Z6	ABS(Anti-Lock Brake System)																																
AXELAMAZDA3	1.6L Z6	BCM/GEM(Body Control Module/Generic Electronic Module)																																
AXELAMAZDA3	1.6L Z6	EATC(Electronic Automatic Temperature Control)																																
AXELAMAZDA3	1.6L Z6	EPS(Electronic-Controlled Power Steering)																																
AXELAMAZDA3	1.6L Z6	IC(Instrument Cluster)																																
AXELAMAZDA3	1.6L Z6	GEM(Generic Electronic Module)																																
AXELAMAZDA3	1.6L Z6	MID(Multi-Information Display)																																
AXELAMAZDA3	1.6L Z6	RCM(Restraint Control Module)																																
AXELAMAZDA3	1.6L Z6	ACU(Audio Control Unit)																																
AXELAMAZDA3	1.6L Z6	PATS(Passive anti theft system)-Beta																																
AXELAMAZDA3	2.0L LF	SYSTEM SEARCH																																
AXELAMAZDA3	2.0L LF	PCM(Powertrain Control Module)																																
AXELAMAZDA3	2.0L LF	TCM(Transmission Control Module)																																
AXELAMAZDA3	2.0L LF	ABS(Anti-Lock Brake System)																																
AXELAMAZDA3	2.0L LF	EATC(Electronic Automatic Temperature Control)																																
AXELAMAZDA3	2.0L LF	EPS(Electronic-Controlled Power Steering)																																
AXELAMAZDA3	2.0L LF	RCM(Restraint Control Module)																																
AXELAMAZDA3	2.0L LF	IC(Instrument Cluster)																																
AXELAMAZDA3	2.0L LF	BCM/GEM(Body Control Module/Generic Electronic Module)									V	V	V	V																				
AXELAMAZDA3	2.0L LF	MID(Multi-Information Display)																																
AXELAMAZDA3	2.0L LF	ACU(Audio Control Unit)																																
AXELAMAZDA3	2.0L LF	GEM(Generic Electronic Module)																																
AXELAMAZDA3	2.0L LF	PATS(Passive anti theft system)-Beta																																
AXELAMAZDA3	2.0L PE	SYSTEM SEARCH																																
AXELAMAZDA3	2.0L PE	PCM(Powertrain Control Module)																																
AXELAMAZDA3	2.0L PE	TCM(Transmission Control Module)																																
AXELAMAZDA3	2.0L PE	4x4(4x4 Control Module)																																
AXELAMAZDA3	2.0L PE	ABS(Anti-Lock Brake System)																																
AXELAMAZDA3	2.0L PE	ACU(Audio Control Unit)																																
AXELAMAZDA3	2.0L PE	EATC(Electronic Automatic Temperature Control)																																
AXELAMAZDA3	2.0L PE	AM(Amplifier Module)																																
AXELAMAZDA3	2.0L PE	AFS(Adaptive Front Lighting System)																																
AXELAMAZDA3	2.0L PE	DSM(Drivers Seat Module)																																
AXELAMAZDA3	2.0L PE	DCDC(DC to DC Converter Control Module)																																
AXELAMAZDA3	2.0L PE	FSC(Forward Sensing Camera)																																
AXELAMAZDA3	2.0L PE	SCBS(Smart City Brake Support)																																
AXELAMAZDA3	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																
AXELAMAZDA3	2.0L PE	EPS(Electronic-Controlled Power Steering)																																
AXELAMAZDA3	2.0L PE	IC(Instrument Cluster)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
AXELAMAZDA3	2.0L PE	RVM(Rear Vehicle Monitoring)																																
AXELAMAZDA3	2.0L PE	RCM(Restraint Control Module)																																
AXELAMAZDA3	2.0L PE	SSU(Smart Start Unit)																																
AXELAMAZDA3	2.0L PE	F_BCM(Front Body Control Module)																																
AXELAMAZDA3	2.0L PE	R_BCM(Rear Body Control Module)																																
AXELAMAZDA3	2.0L PE	CMU(Connectivity Master Unit)																																
AXELAMAZDA3	2.3L L3_T	SYSTEM SEARCH																																
AXELAMAZDA3	2.3L L3_T	PCM(Powertrain Control Module)																																
AXELAMAZDA3	2.3L L3_T	TCM(Transmission Control Module)																																
AXELAMAZDA3	2.3L L3_T	ABS(Anti-Lock Brake System)																																
AXELAMAZDA3	2.3L L3_T	EPS(Electronic-Controlled Power Steering)																																
AXELAMAZDA3	2.3L L3_T	EATC(Electronic Automatic Temperature Control)																																
AXELAMAZDA3	2.3L L3_T	BCM/GEM(Body Control Module/Generic Electronic Module)									V	V	V	V																				
AXELAMAZDA3	2.3L L3_T	IC(Instrument Cluster)																																
AXELAMAZDA3	2.3L L3_T	RCM(Restraint Control Module)																																
AXELAMAZDA3	2.3L L3_T	AFS(Adaptive Front Lighting System)																																
AXELAMAZDA3	2.3L L3_T	MID(Multi-Information Display)																																
AXELAMAZDA3	2.3L L3_T	ACU(Audio Control Unit)																																
AXELAMAZDA3	2.3L L3_T	LCM(Lighting Control Module)																																
AXELAMAZDA3	2.3L L3_T	RKE(Remote Keyless Entry)																																
AXELAMAZDA3	2.3L L3_T	TPM(Tire Pressure Monitor)																																
AXELAMAZDA3	2.3L L3_T	PATS(Passive anti theft system)-Beta																																
AXELAMAZDA3	2.5L L5	SYSTEM SEARCH																																
AXELAMAZDA3	2.5L L5	PCM(Powertrain Control Module)																																
AXELAMAZDA3	2.5L L5	TCM(Transmission Control Module)																																
AXELAMAZDA3	2.5L L5	ABS(Anti-Lock Brake System)																																
AXELAMAZDA3	2.5L L5	EPS(Electronic-Controlled Power Steering)																																
AXELAMAZDA3	2.5L L5	EATC(Electronic Automatic Temperature Control)																																
AXELAMAZDA3	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)									V	V	V	V																				
AXELAMAZDA3	2.5L L5	IC(Instrument Cluster)																																
AXELAMAZDA3	2.5L L5	RCM(Restraint Control Module)																																
AXELAMAZDA3	2.5L L5	MID(Multi-Information Display)																																
AXELAMAZDA3	2.5L L5	ACU(Audio Control Unit)																																
AXELAMAZDA3	2.5L L5	AFS(Adaptive Front Lighting System)																																
AXELAMAZDA3	2.5L L5	RKE(Remote Keyless Entry)																																
AXELAMAZDA3	2.5L PY	SYSTEM SEARCH																																
AXELAMAZDA3	2.5L PY	PCM(Powertrain Control Module)																																
AXELAMAZDA3	2.5L PY	TCM(Transmission Control Module)																																
AXELAMAZDA3	2.5L PY	4x4(4x4 Control Module)																																
AXELAMAZDA3	2.5L PY	ABS(Anti-Lock Brake System)																																
AXELAMAZDA3	2.5L PY	AM(Amplifier Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
AXELAMAZDA3	2.5L PY	DSM(Drivers Seat Module)																																
AXELAMAZDA3	2.5L PY	EATC(Electronic Automatic Temperature Control)																																
AXELAMAZDA3	2.5L PY	EPB(Electonic Parking Brake)																																
AXELAMAZDA3	2.5L PY	EPS(Electronic-Controlled Power Steering)																																
AXELAMAZDA3	2.5L PY	IC(Instrument Cluster)																																
AXELAMAZDA3	2.5L PY	RCM(Restraint Control Module)																																
AXELAMAZDA3	2.5L PY	AFS(Adaptive Front Lighting System)																																
AXELAMAZDA3	2.5L PY	FSC(Forward Sensing Camera)																																
AXELAMAZDA3	2.5L PY	SSU(Smart Start Unit)																																
AXELAMAZDA3	2.5L PY	F_BCM(Front Body Control Module)																																
AXELAMAZDA3	2.5L PY	R_BCM(Rear Body Control Module)																																
AXELAMAZDA3	2.5L PY	SCBS(Smart City Brake Support)																																
AXELAMAZDA3	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																
AXELAMAZDA3	2.5L PY	ACU(Audio Control Unit)																																
AXELAMAZDA3	2.5L PY	CMU(Connectivity Master Unit)																																
AXELAMAZDA3	2.5L PY	BSML(Blind Spot Monitoring Left)																																
AXELAMAZDA3	2.5L PY	BSMR(Blind Spot Monitoring Right)																																
AXELAMAZDA3	2.0L RF_T (Diesel)	SYSTEM SEARCH																																
AXELAMAZDA3	2.0L RF_T (Diesel)	PCM(Powertrain Control Module)																																
AXELAMAZDA3	2.0L RF_T (Diesel)	ABS(Anti-Lock Brake System)																																
AXELAMAZDA3	2.0L RF_T (Diesel)	RCM(Restraint Control Module)																																
AXELAMAZDA3	2.0L RF_T (Diesel)	PATS(Passive anti theft system)-Beta																																
AXELAMAZDA3	2.2L R2_T (Diesel)	SYSTEM SEARCH																																
AXELAMAZDA3	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)																																
AXELAMAZDA3	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																																
AXELAMAZDA3	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																																
AXELAMAZDA3	2.2L R2_T (Diesel)	BCM/GEM(Body Control Module/Generic Electronic Module)																																
AXELAMAZDA3	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																																
AXELAMAZDA3	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																
AXELAMAZDA3	2.2L R2_T (Diesel)	MID(Multi-Information Display)																																
AXELAMAZDA3	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																																
AXELAMAZDA3	2.2L SH (Diesel)	SYSTEM SEARCH																																
AXELAMAZDA3	2.2L SH (Diesel)	PCM(Powertrain Control Module)																																
AXELAMAZDA3	2.2L SH (Diesel)	TCM(Transmission Control Module)																																
AXELAMAZDA3	2.2L SH (Diesel)	4x4(4x4 Control Module)																																
AXELAMAZDA3	2.2L SH (Diesel)	ABS(Anti-Lock Brake System)																																
AXELAMAZDA3	2.2L SH (Diesel)	ACU(Audio Control Unit)																																
AXELAMAZDA3	2.2L SH (Diesel)	CMU(Connectivity Master Unit)																																
AXELAMAZDA3	2.2L SH (Diesel)	EATC(Electronic Automatic Temperature Control)																																
AXELAMAZDA3	2.2L SH (Diesel)	AM(Amplifier Module)																																
AXELAMAZDA3	2.2L SH (Diesel)	AFS(Adaptive Front Lighting System)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
AXELAMAZDA3	2.2L SH (Diesel)	DSM(Drivers Seat Module)																																
AXELAMAZDA3	2.2L SH (Diesel)	DCDC(DC to DC Converter Control Module)																																
AXELAMAZDA3	2.2L SH (Diesel)	FSC(Forward Sensing Camera)																																
AXELAMAZDA3	2.2L SH (Diesel)	SCBS(Smart City Brake Support)																																
AXELAMAZDA3	2.2L SH (Diesel)	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																
AXELAMAZDA3	2.2L SH (Diesel)	EPB(Electonic Parking Brake)																																
AXELAMAZDA3	2.2L SH (Diesel)	EPS(Electronic-Controlled Power Steering)																																
AXELAMAZDA3	2.2L SH (Diesel)	IC(Instrument Cluster)																																
AXELAMAZDA3	2.2L SH (Diesel)	RVM(Rear Vehicle Monitoring)																																
AXELAMAZDA3	2.2L SH (Diesel)	RCM(Restraint Control Module)																																
AXELAMAZDA3	2.2L SH (Diesel)	SSU(Smart Start Unit)																																
AXELAMAZDA3	2.2L SH (Diesel)	F_BCM(Front Body Control Module)																																
AXELAMAZDA3	2.2L SH (Diesel)	R_BCM(Rear Body Control Module)																																
PREMACYMAZDA5	1.6L Y6 (BETA)	SYSTEM SEARCH																																
PREMACYMAZDA5	1.6L Y6 (BETA)	PCM(Powertrain Control Module)																																
PREMACYMAZDA5	1.6L Y6 (BETA)	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	1.6L Y6 (BETA)	BCM/GEM(Body Control Module/Generic Electronic Module)																																
PREMACYMAZDA5	1.6L Y6 (BETA)	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	1.6L Y6 (BETA)	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	1.6L Y6 (BETA)	IC(Instrument Cluster)																																
PREMACYMAZDA5	1.6L Y6 (BETA)	LPSDM(Left Power Sliding Module)																																
PREMACYMAZDA5	1.6L Y6 (BETA)	RCM(Restraint Control Module)																																
PREMACYMAZDA5	1.6L Y6 (BETA)	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	1.6L Y6 (BETA)	RPSDM(Right Power Sliding Module)																																
PREMACYMAZDA5	1.6L Y6 (BETA)	ACU(Audio Control Unit)																																
PREMACYMAZDA5	1.8L (BETA)	2005	SYSTEM SEARCH																															
PREMACYMAZDA5	1.8L (BETA)	2005	PCM(Powertrain Control Module)-MT																															
PREMACYMAZDA5	1.8L (BETA)	2005	ABS(Anti-Lock Brake System)																															
PREMACYMAZDA5	1.8L (BETA)	2005	EATC(Electronic Automatic Temperature Control)																															
PREMACYMAZDA5	1.8L (BETA)	2005	EPS(Electronic-Controlled Power Steering)																															
PREMACYMAZDA5	1.8L (BETA)	2005	GEM(Generic Electronic Module)												V																			
PREMACYMAZDA5	1.8L (BETA)	2005	RCM(Restraint Control Module)																															
PREMACYMAZDA5	1.8L (BETA)	2005	IC(Instrument Cluster)																															
PREMACYMAZDA5	1.8L (BETA)	2005	LPSDM(Left Power Sliding Module)																															
PREMACYMAZDA5	1.8L (BETA)	2005	RPSDM(Right Power Sliding Module)																															
PREMACYMAZDA5	1.8L (BETA)	2005	RKE(Remote Keyless Entry)																															
PREMACYMAZDA5	1.8L (BETA)	2005	PATS(Passive anti theft system)-Beta																															
PREMACYMAZDA5	2.0L LF	2005	SYSTEM SEARCH																															
PREMACYMAZDA5	2.0L LF	2005	PCM(Powertrain Control Module)	ALL																														
PREMACYMAZDA5	2.0L LF	2005	PCM(Powertrain Control Module)	AT																														
PREMACYMAZDA5	2.0L LF	2005	ABS(Anti-Lock Brake System)													V																		

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
PREMACYMAZDA5	2.0L LF	2005	EPS(Electronic-Controlled Power Steering)																															
PREMACYMAZDA5	2.0L LF	2005	GEM(Generic Electronic Module)												V																			
PREMACYMAZDA5	2.0L LF	2005	RCM(Restraint Control Module)																															
PREMACYMAZDA5	2.0L LF	2005	EATC(Electronic Automatic Temperature Control)																															
PREMACYMAZDA5	2.0L LF	2005	IC(Instrument Cluster)																															
PREMACYMAZDA5	2.0L LF	2005	RKE(Remote Keyless Entry)																															
PREMACYMAZDA5	2.0L LF	2005	PATS(Passive anti theft system)-Beta																															
PREMACYMAZDA5	2.0L LF	2007	SYSTEM SEARCH																															
PREMACYMAZDA5	2.0L LF	2007	PCM(Powertrain Control Module)														V	V	V															
PREMACYMAZDA5	2.0L LF	2007	ABS(Anti-Lock Brake System)																															
PREMACYMAZDA5	2.0L LF	2007	EPS(Electronic-Controlled Power Steering)																															
PREMACYMAZDA5	2.0L LF	2007	GEM(Generic Electronic Module)												V																			
PREMACYMAZDA5	2.0L LF	2007	RCM(Restraint Control Module)																															
PREMACYMAZDA5	2.0L LF	2007	EATC(Electronic Automatic Temperature Control)																															
PREMACYMAZDA5	2.0L LF	2007	IC(Instrument Cluster)																															
PREMACYMAZDA5	2.0L LF	2007	RKE(Remote Keyless Entry)																															
PREMACYMAZDA5	2.0L LF	2007	PATS(Passive anti theft system)-Beta																															
PREMACYMAZDA5	2.0L LF	2010~	SYSTEM SEARCH																															
PREMACYMAZDA5	2.0L LF	2010~	PCM(Powertrain Control Module)																	V														
PREMACYMAZDA5	2.0L LF	2010~	ABS(Anti-Lock Brake System)																															
PREMACYMAZDA5	2.0L LF	2010~	BCM/GEM(Body Control Module/Generic Electronic Module)																															
PREMACYMAZDA5	2.0L LF	2010~	EATC(Electronic Automatic Temperature Control)																															
PREMACYMAZDA5	2.0L LF	2010~	EPS(Electronic-Controlled Power Steering)																															
PREMACYMAZDA5	2.0L LF	2010~	IC(Instrument Cluster)																															
PREMACYMAZDA5	2.0L LF	2010~	RKE(Remote Keyless Entry)																															
PREMACYMAZDA5	2.0L LF	2010~	LPSDM(Left Power Sliding Module)																															
PREMACYMAZDA5	2.0L LF	2010~	RCM(Restraint Control Module)																															
PREMACYMAZDA5	2.0L LF	2010~	RPSDM(Right Power Sliding Module)																															
PREMACYMAZDA5	2.0L LF	2010~	TCM(Transmission Control Module)																															
PREMACYMAZDA5	2.0L RF_T (Diesel)	SYSTEM SEARCH																																
PREMACYMAZDA5	2.0L RF_T (Diesel)	PCM(Powertrain Control Module)																																
PREMACYMAZDA5	2.0L RF_T (Diesel)	TCM(Transmission Control Module)																																
PREMACYMAZDA5	2.0L RF_T (Diesel)	ABS(Anti-Lock Brake System)																			V	V												
PREMACYMAZDA5	2.0L RF_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.0L RF_T (Diesel)	GEM(Generic Electronic Module)													V																			
PREMACYMAZDA5	2.0L RF_T (Diesel)	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.0L RF_T (Diesel)	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.0L RF_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																					V											
PREMACYMAZDA5	2.0L RF_T (Diesel)	RKE(Remote Keyless Entry)																																
PREMACYMAZDA5	2.0L RF_T (Diesel)	PATS(Passive anti theft system)-Beta																																
PREMACYMAZDA5	2.3L L3	SYSTEM SEARCH																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
PREMACYMAZDA5	2.3L L3	PCM(Powertrain Control Module)																																
PREMACYMAZDA5	2.3L L3	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	2.3L L3	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.3L L3	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.3L L3	GEM(Generic Electronic Module)													V																			
PREMACYMAZDA5	2.3L L3	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.3L L3	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.3L L3	TPM(Tire Pressure Monitor)																																
PREMACYMAZDA5	2.5L L5	SYSTEM SEARCH																																
PREMACYMAZDA5	2.5L L5	PCM(Powertrain Control Module)																																
PREMACYMAZDA5	2.5L L5	TCM(Transmission Control Module)																																
PREMACYMAZDA5	2.5L L5	ABS(Anti-Lock Brake System)																																
PREMACYMAZDA5	2.5L L5	EPS(Electronic-Controlled Power Steering)																																
PREMACYMAZDA5	2.5L L5	RCM(Restraint Control Module)																																
PREMACYMAZDA5	2.5L L5	IC(Instrument Cluster)																																
PREMACYMAZDA5	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																
PREMACYMAZDA5	2.5L L5	LPSDM(Left Power Sliding Module)																																
PREMACYMAZDA5	2.5L L5	RPSDM(Right Power Sliding Module)																																
PREMACYMAZDA5	2.5L L5	EATC(Electronic Automatic Temperature Control)																																
PREMACYMAZDA5	2.5L L5	AFS(Adaptive Front Lighting System)																																
PREMACYMAZDA5	2.5L L5	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	1.8L L8	SYSTEM SEARCH																																
ATENZAMAZDA6	1.8L L8	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	1.8L L8	TCM(Transmission Control Module)																																
ATENZAMAZDA6	1.8L L8	ABS(Anti-Lock Brake System)																			V	V												
ATENZAMAZDA6	1.8L L8	GEM(Generic Electronic Module)																																
ATENZAMAZDA6	1.8L L8	IC(Instrument Cluster)																																
ATENZAMAZDA6	1.8L L8	LHID(Left High Intensity Discharge Lamp)																						V										
ATENZAMAZDA6	1.8L L8	RCM(Restraint Control Module)																																
ATENZAMAZDA6	1.8L L8	RHID(Right High Intensity Discharge Lamp)																																
ATENZAMAZDA6	1.8L L8	RKE(Remote Keyless Entry)																																
ATENZAMAZDA6	1.8L L8	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.0L PE	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L PE	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.0L PE	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.0L PE	4x4(4x4 Control Module)																																
ATENZAMAZDA6	2.0L PE	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.0L PE	ACU(Audio Control Unit)																																
ATENZAMAZDA6	2.0L PE	EATC(Electronic Automatic Temperature Control)																																
ATENZAMAZDA6	2.0L PE	EPB(Electonic Parking Brake)																																
ATENZAMAZDA6	2.0L PE	AM(Amplifier Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
ATENZAMAZDA6	2.0L PE	AFS(Adaptive Front Lighting System)																																
ATENZAMAZDA6	2.0L PE	DSM(Drivers Seat Module)																																
ATENZAMAZDA6	2.0L PE	DCDC(DC to DC Converter Control Module)																																
ATENZAMAZDA6	2.0L PE	FSC(Forward Sensing Camera)																																
ATENZAMAZDA6	2.0L PE	SCBS(Smart City Brake Support)																																
ATENZAMAZDA6	2.0L PE	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																
ATENZAMAZDA6	2.0L PE	EPS(Electronic-Controlled Power Steering)																																
ATENZAMAZDA6	2.0L PE	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.0L PE	RVM(Rear Vehicle Monitoring)																																
ATENZAMAZDA6	2.0L PE	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.0L PE	SSU(Smart Start Unit)																																
ATENZAMAZDA6	2.0L PE	F_BCM(Front Body Control Module)																																
ATENZAMAZDA6	2.0L PE	R_BCM(Rear Body Control Module)																																
ATENZAMAZDA6	2.0L PE	CMU(Connectivity Master Unit)																																
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	SYSTEM SEARCH																															
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	PCM(Powertrain Control Module)																															
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	TCM(Transmission Control Module)																															
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	ABS(Anti-Lock Brake System)																															
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	RCM(Restraint Control Module)																															
ATENZAMAZDA6	2.0L RF (Diesel)	2.0 DT Sal.H/b Est	PATS(Passive anti theft system)-Beta																															
ATENZAMAZDA6	2.0L LF	SYSTEM SEARCH																																
ATENZAMAZDA6	2.0L LF	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.0L LF	ABS(Anti-Lock Brake System)																			V	V												
ATENZAMAZDA6	2.0L LF	ACU(Audio Control Unit)																																
ATENZAMAZDA6	2.0L LF	BCM/GEM(Body Control Module/Generic Electronic Module)																																
ATENZAMAZDA6	2.0L LF	EATC(Electronic Automatic Temperature Control)																																
ATENZAMAZDA6	2.0L LF	EPS(Electronic-Controlled Power Steering)																							V									
ATENZAMAZDA6	2.0L LF	GEM(Generic Electronic Module)																																
ATENZAMAZDA6	2.0L LF	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.0L LF	LCM(Lighting Control Module)																																
ATENZAMAZDA6	2.0L LF	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.0L LF	RHID(Right High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.0L LF	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.0L LF	LHID(Left High Intensity Discharge Lamp)																						V										
ATENZAMAZDA6	2.0L LF	RKE(Remote Keyless Entry)																																
ATENZAMAZDA6	2.0L LF	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.3L L3	2.3L	SYSTEM SEARCH																															
ATENZAMAZDA6	2.3L L3	2.3L	PCM(Powertrain Control Module)																															
ATENZAMAZDA6	2.3L L3	2.3L	TCM(Transmission Control Module)																															
ATENZAMAZDA6	2.3L L3	2.3L	ABS(Anti-Lock Brake System)																															
ATENZAMAZDA6	2.3L L3	2.3L	IC(Instrument Cluster)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
ATENZAMAZDA6	2.3L L3	2.3L	GEM(Generic Electronic Module)																															
ATENZAMAZDA6	2.3L L3	2.3L	RHID(Right High Intensity Discharge Lamp)																															
ATENZAMAZDA6	2.3L L3	2.3L	LHID(Left High Intensity Discharge Lamp)																					V										
ATENZAMAZDA6	2.3L L3	2.3L	RCM(Restraint Control Module)																															
ATENZAMAZDA6	2.3L L3	2.3L	PATS(Passive anti theft system)-Beta																															
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	SYSTEM SEARCH																															
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	PCM(Powertrain Control Module)																															
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	TCM(Transmission Control Module)																															
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	ABS(Anti-Lock Brake System)																															
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	RCM(Restraint Control Module)																															
ATENZAMAZDA6	2.3L L3	2.3i Est - 4WD	PATS(Passive anti theft system)-Beta																															
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	SYSTEM SEARCH																															
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	PCM(Powertrain Control Module)																															
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	TCM(Transmission Control Module)																															
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	ABS(Anti-Lock Brake System)																															
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	RCM(Restraint Control Module)																															
ATENZAMAZDA6	2.3L L3	2.3i H/b - Sport	PATS(Passive anti theft system)-Beta																															
ATENZAMAZDA6	2.3L L3_T	SYSTEM SEARCH																																
ATENZAMAZDA6	2.3L L3_T	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.3L L3_T	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.3L L3_T	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.3L L3_T	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.3L L3_T	LHID(Left High Intensity Discharge Lamp)																						V										
ATENZAMAZDA6	2.3L L3_T	RHID(Right High Intensity Discharge Lamp)																																
ATENZAMAZDA6	2.3L L3_T	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.3L L3_T	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	SYSTEM SEARCH																															
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	PCM(Powertrain Control Module)																															
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	TCM(Transmission Control Module)																															
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	ABS(Anti-Lock Brake System)																															
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	RCM(Restraint Control Module)																															
ATENZAMAZDA6	2.3L L3-VDT	2.3i Sal - MPS Turbo	PATS(Passive anti theft system)-Beta																															
ATENZAMAZDA6	2.5L L5	SYSTEM SEARCH																																
ATENZAMAZDA6	2.5L L5	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.5L L5	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.5L L5	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.5L L5	EPS(Electronic-Controlled Power Steering)																							V									
ATENZAMAZDA6	2.5L L5	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.5L L5	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.5L L5	BCM/GEM(Body Control Module/Generic Electronic Module)																																
ATENZAMAZDA6	2.5L L5	EATC(Electronic Automatic Temperature Control)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
ATENZAMAZDA6	2.5L L5	AFS(Adaptive Front Lighting System)																																
ATENZAMAZDA6	2.5L L5	LCM(Lighting Control Module)																																
ATENZAMAZDA6	2.5L L5	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.5L PY	SYSTEM SEARCH																																
ATENZAMAZDA6	2.5L PY	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.5L PY	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.5L PY	4x4(4x4 Control Module)																																
ATENZAMAZDA6	2.5L PY	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.5L PY	AM(Amplifier Module)																																
ATENZAMAZDA6	2.5L PY	BSML(Blind Spot Monitoring Left)																																
ATENZAMAZDA6	2.5L PY	BSMR(Blind Spot Monitoring Right)																																
ATENZAMAZDA6	2.5L PY	DSM(Drivers Seat Module)																																
ATENZAMAZDA6	2.5L PY	DCDC(DC to DC Converter Control Module)																																
ATENZAMAZDA6	2.5L PY	EATC(Electronic Automatic Temperature Control)																																
ATENZAMAZDA6	2.5L PY	EPB(Electonic Parking Brake)																																
ATENZAMAZDA6	2.5L PY	EPS(Electronic-Controlled Power Steering)																																
ATENZAMAZDA6	2.5L PY	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.5L PY	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.5L PY	AFS(Adaptive Front Lighting System)																																
ATENZAMAZDA6	2.5L PY	FSC(Forward Sensing Camera)																																
ATENZAMAZDA6	2.5L PY	SSU(Smart Start Unit)																																
ATENZAMAZDA6	2.5L PY	F_BCM(Front Body Control Module)																																
ATENZAMAZDA6	2.5L PY	R_BCM(Rear Body Control Module)																																
ATENZAMAZDA6	2.5L PY	SCBS(Smart City Brake Support)																																
ATENZAMAZDA6	2.5L PY	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																
ATENZAMAZDA6	2.5L PY	ACU(Audio Control Unit)																																
ATENZAMAZDA6	2.5L PY	CMU(Connectivity Master Unit)																																
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	SYSTEM SEARCH																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	PCM(Powertrain Control Module)																						V	V	V							
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	ABS(Anti-Lock Brake System)																		V	V												
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	FFH(Fuel Fired Coolant Heating Module)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	IC(Instrument Cluster)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	LHID(Left High Intensity Discharge Lamp)																					V										
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	RHID(Right High Intensity Discharge Lamp)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	~ 2006	RCM(Restraint Control Module)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	SYSTEM SEARCH																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	PCM(Powertrain Control Module)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	ABS(Anti-Lock Brake System)																		V	V												
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	ACU(Audio Control Unit)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	BCM/GEM(Body Control Module/Generic Electronic Module)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	GEM(Generic Electronic Module)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	EATC(Electronic Automatic Temperature Control)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	IC(Instrument Cluster)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	EPS(Electronic-Controlled Power Steering)																						V									
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	FFH(Fuel Fired Coolant Heating Module)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	RCM(Restraint Control Module)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	LCM(Lighting Control Module)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	RVM(Rear Vehicle Monitoring)																															
ATENZAMAZDA6	2.0L RF_T (Diesel)	2006~	PATS(Passive anti theft system)-Beta																															
ATENZAMAZDA6	2.2L R2_T (Diesel)	SYSTEM SEARCH																																
ATENZAMAZDA6	2.2L R2_T (Diesel)	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.2L R2_T (Diesel)	ABS(Anti-Lock Brake System)																			V	V												
ATENZAMAZDA6	2.2L R2_T (Diesel)	ACU(Audio Control Unit)																																
ATENZAMAZDA6	2.2L R2_T (Diesel)	BCM/GEM(Body Control Module/Generic Electronic Module)																																
ATENZAMAZDA6	2.2L R2_T (Diesel)	EATC(Electronic Automatic Temperature Control)																																
ATENZAMAZDA6	2.2L R2_T (Diesel)	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.2L R2_T (Diesel)	EPS(Electronic-Controlled Power Steering)																							V									
ATENZAMAZDA6	2.2L R2_T (Diesel)	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.2L R2_T (Diesel)	LCM(Lighting Control Module)																																
ATENZAMAZDA6	2.2L R2_T (Diesel)	FFH(Fuel Fired Coolant Heating Module)																																
ATENZAMAZDA6	2.2L R2_T (Diesel)	PATS(Passive anti theft system)-Beta																																
ATENZAMAZDA6	2.2L SH (Diesel)	SYSTEM SEARCH																																
ATENZAMAZDA6	2.2L SH (Diesel)	PCM(Powertrain Control Module)																																
ATENZAMAZDA6	2.2L SH (Diesel)	TCM(Transmission Control Module)																																
ATENZAMAZDA6	2.2L SH (Diesel)	4x4(4x4 Control Module)																																
ATENZAMAZDA6	2.2L SH (Diesel)	ABS(Anti-Lock Brake System)																																
ATENZAMAZDA6	2.2L SH (Diesel)	AM(Amplifier Module)																																
ATENZAMAZDA6	2.2L SH (Diesel)	CMU(Connectivity Master Unit)																																
ATENZAMAZDA6	2.2L SH (Diesel)	EATC(Electronic Automatic Temperature Control)																																
ATENZAMAZDA6	2.2L SH (Diesel)	AFS(Adaptive Front Lighting System)																																
ATENZAMAZDA6	2.2L SH (Diesel)	DSM(Drivers Seat Module)																																
ATENZAMAZDA6	2.2L SH (Diesel)	DCDC(DC to DC Converter Control Module)																																
ATENZAMAZDA6	2.2L SH (Diesel)	FSC(Forward Sensing Camera)																																
ATENZAMAZDA6	2.2L SH (Diesel)	SCBS(Smart City Brake Support)																																
ATENZAMAZDA6	2.2L SH (Diesel)	SBS/MRCC(Smart Brake Support/Mazda Radar Cruise Control)																																
ATENZAMAZDA6	2.2L SH (Diesel)	EPB(Electonic Parking Brake)																																
ATENZAMAZDA6	2.2L SH (Diesel)	EPS(Electronic-Controlled Power Steering)																																
ATENZAMAZDA6	2.2L SH (Diesel)	IC(Instrument Cluster)																																
ATENZAMAZDA6	2.2L SH (Diesel)	RVM(Rear Vehicle Monitoring)																																
ATENZAMAZDA6	2.2L SH (Diesel)	RCM(Restraint Control Module)																																
ATENZAMAZDA6	2.2L SH (Diesel)	SSU(Smart Start Unit)																																
ATENZAMAZDA6	2.2L SH (Diesel)	F_BCM(Front Body Control Module)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
ATENZAMAZDA6	2.2L SH (Diesel)	R_BCM(Rear Body Control Module)																																
ATENZAMAZDA6	2.2L SH (Diesel)	BSM(Blind Spot Monitoring)																																
ATENZAMAZDA6	2.2L SH (Diesel)	PSM(Parking Sensor Module)																																
MPVMAZDA8	2.3L L3	SYSTEM SEARCH																																
MPVMAZDA8	2.3L L3	PCM(Powertrain Control Module)															V	V	V															
MPVMAZDA8	2.3L L3	ABS(Anti-Lock Brake System)																																
MPVMAZDA8	2.3L L3_T	SYSTEM SEARCH																																
MPVMAZDA8	2.3L L3_T	PCM(Powertrain Control Module)																																
MPVMAZDA8	2.3L L3_T	ABS(Anti-Lock Brake System)																																
MPVMAZDA8	2.3L L3_T	AM(Amplifier Module)																																
MPVMAZDA8	2.3L L3_T	GEM(Generic Electronic Module)																																
MPVMAZDA8	2.3L L3_T	HCM(Headlamp Control Module)																																
MPVMAZDA8	2.3L L3_T	ICCM(Intelligent Cruise Control Module)-Beta Test																																
MPVMAZDA8	2.3L L3_T	IC(Instrument Cluster)																																
MPVMAZDA8	2.3L L3_T	LTM(Liftgate/Trunk Module)-Beta Test																																
MPVMAZDA8	2.3L L3_T	RCM(Restraint Control Module)																																
MPVMAZDA8	2.3L L3_T	RKE(Remote Keyless Entry)																																
MPVMAZDA8	2.3L L3_T	TCM(Transmission Control Module)																																
MPVMAZDA8	2.3L L3_T	LCM(Lighting Control Module)-Beta Test													V																			
MPVMAZDA8	2.3L L3_T	4x4(4x4 Control Module)																																
MPVMAZDA8	2.3L L3_T	LPSDM(Left Power Sliding Door Module)																																
MPVMAZDA8	2.3L L3_T	RPSDM(Right Power Sliding Door Module)																																
ROADSTERMX-5	North America/General specs	2.0L LF	SYSTEM SEARCH																															
ROADSTERMX-5	North America/General specs	2.0L LF	PCM(Powertrain Control Module)	2006~																														
ROADSTERMX-5	North America/General specs	2.0L LF	PCM(Powertrain Control Module)	2008~																														
ROADSTERMX-5	North America/General specs	2.0L LF	ABS(Anti-Lock Brake System)																															
ROADSTERMX-5	North America/General specs	2.0L LF	IC(Instrument Cluster)																															
ROADSTERMX-5	North America/General specs	2.0L LF	RCM(Restraint Control Module)																															
ROADSTERMX-5	North America/General specs	2.0L LF	RHT(Retractable Hard Top)																															
ROADSTERMX-5	North America/General specs	2.0L LF	RKE(Remote Keyless Entry)																															
ROADSTERMX-5	North America/General specs	2.0L LF	TCM(Transmission Control Module)																															
ROADSTERMX-5	North America/General specs	2.0L LF	PATS(Passive anti theft system)-Beta																															
ROADSTERMX-5	North America/General specs	2.0L LF	DHS(Deployable Hood System)																															
ROADSTERMX-5	North America/General specs	1.5L P5	SYSTEM SEARCH																															
ROADSTERMX-5	North America/General specs	1.5L P5	PCM(Powertrain Control Module)																															
ROADSTERMX-5	North America/General specs	1.5L P5	ABS(Anti-Lock Brake System)																															
ROADSTERMX-5	North America/General specs	1.5L P5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																															
ROADSTERMX-5	North America/General specs	1.5L P5	AM(Amplifier Module)																															
ROADSTERMX-5	North America/General specs	1.5L P5	DCDC(DC to DC Converter Control Module)																															
ROADSTERMX-5	North America/General specs	1.5L P5	EATC(Electronic Automatic Temperature Control)																															
ROADSTERMX-5	North America/General specs	1.5L P5	EPS(Electronic-Controlled Power Steering)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
ROADSTERMX-5	North America/General specs	1.5L P5	EVP(Electronical VACUUM PUMP)																															
ROADSTERMX-5	North America/General specs	1.5L P5	IC(Instrument Cluster)																															
ROADSTERMX-5	North America/General specs	1.5L P5	RCM(Restraint Control Module)																															
ROADSTERMX-5	North America/General specs	1.5L P5	TCM(Transmission Control Module)																															
ROADSTERMX-5	North America/General specs	1.5L P5	BSM(Blind Spot Monitoring)																															
ROADSTERMX-5	North America/General specs	1.5L P5	BCM(Body Control Module)																															
ROADSTERMX-5	North America/General specs	1.5L P5	FSC(Forward Sensing Camera)																															
ROADSTERMX-5	North America/General specs	1.5L P5	SSU(Smart Start Unit)																															
ROADSTERMX-5	North America/General specs	1.5L P5	CMU(Connectivity Master Unit)																															
ROADSTERMX-5	North America/General specs	1.5L P5	ESU(Electric Supply Unit)																															
ROADSTERMX-5	Europe/General Specs	2.0L LF	SYSTEM SEARCH																															
ROADSTERMX-5	Europe/General Specs	2.0L LF	PCM(Powertrain Control Module)																															
ROADSTERMX-5	Europe/General Specs	2.0L LF	ABS(Anti-Lock Brake System)																															
ROADSTERMX-5	Europe/General Specs	2.0L LF	IC(Instrument Cluster)																															
ROADSTERMX-5	Europe/General Specs	2.0L LF	RCM(Restraint Control Module)																															
ROADSTERMX-5	Europe/General Specs	2.0L LF	RHT(Retractable Hard Top)																															
ROADSTERMX-5	Europe/General Specs	2.0L LF	RKE(Remote Keyless Entry)																															
ROADSTERMX-5	Europe/General Specs	2.0L LF	TCM(Transmission Control Module)																															
ROADSTERMX-5	Europe/General Specs	2.0L LF	PATS(Passive anti theft system)-Beta																															
ROADSTERMX-5	Europe/General Specs	2.0L LF	DHS(Deployable Hood System)																															
ROADSTERMX-5	Europe/General Specs	1.8L L8	SYSTEM SEARCH																															
ROADSTERMX-5	Europe/General Specs	1.8L L8	PCM(Powertrain Control Module)																															
ROADSTERMX-5	Europe/General Specs	1.8L L8	ABS(Anti-Lock Brake System)																															
ROADSTERMX-5	Europe/General Specs	1.8L L8	IC(Instrument Cluster)																															
ROADSTERMX-5	Europe/General Specs	1.8L L8	RCM(Restraint Control Module)																															
ROADSTERMX-5	Europe/General Specs	1.8L L8	RHT(Retractable Hard Top)																															
ROADSTERMX-5	Europe/General Specs	1.8L L8	RKE(Remote Keyless Entry)																															
ROADSTERMX-5	Europe/General Specs	1.8L L8	TCM(Transmission Control Module)																															
ROADSTERMX-5	Europe/General Specs	1.8L L8	PATS(Passive anti theft system)-Beta																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	SYSTEM SEARCH																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	PCM(Powertrain Control Module)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	ABS(Anti-Lock Brake System)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	AFS/ALM(Adaptive Front Lighting System/Auto Leveling Module)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	AM(Amplifier Module)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	DCDC(DC to DC Converter Control Module)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	EATC(Electronic Automatic Temperature Control)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	EPS(Electronic-Controlled Power Steering)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	EVP(Electronical VACUUM PUMP)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	IC(Instrument Cluster)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	RCM(Restraint Control Module)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	TCM(Transmission Control Module)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
ROADSTERMX-5	Europe/General Specs	1.5L P5	BSM(Blind Spot Monitoring)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	BCM(Body Control Module)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	FSC(Forward Sensing Camera)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	SSU(Smart Start Unit)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	CMU(Connectivity Master Unit)																															
ROADSTERMX-5	Europe/General Specs	1.5L P5	ESU(Electric Supply Unit)																															
RX-8	North America Spec	13B	SYSTEM SEARCH																															
RX-8	North America Spec	13B	PCM(Powertrain Control Module)																															
RX-8	North America Spec	13B	PATS(Passive anti theft system)-Beta																															
RX-8	North America Spec	13B	ABS(Anti-Lock Brake System)																		V	V												
RX-8	North America Spec	13B	EPS(Electronic-Controlled Power Steering)																						V									
RX-8	North America Spec	13B	IC(Instrument Cluster)																															
RX-8	North America Spec	13B	RCM(Restraint Control Module)																															
RX-8	North America Spec	13B	RKE(Remote Keyless Entry)																															
RX-8	North America Spec	13B	TCM(Transmission Control Module)																															
RX-8	North America Spec	13B	TPM(Tire Pressure Monitor)																															
RX-8	North America Spec	13B	LCM(Lighting Control Module)																															
RX-8	North America Spec	13B-MSP High-Power	SYSTEM SEARCH																															
RX-8	North America Spec	13B-MSP High-Power	PCM(Powertrain Control Module)																															
RX-8	North America Spec	13B-MSP High-Power	PATS(Passive anti theft system)-Beta																															
RX-8	North America Spec	13B-MSP High-Power	ABS(Anti-Lock Brake System)																		V	V												
RX-8	North America Spec	13B-MSP High-Power	EPS(Electronic-Controlled Power Steering)																						V									
RX-8	North America Spec	13B-MSP High-Power	IC(Instrument Cluster)																															
RX-8	North America Spec	13B-MSP High-Power	RCM(Restraint Control Module)																															
RX-8	North America Spec	13B-MSP High-Power	RKE(Remote Keyless Entry)																															
RX-8	North America Spec	13B-MSP High-Power	TCM(Transmission Control Module)																															
RX-8	North America Spec	13B-MSP High-Power	TPM(Tire Pressure Monitor)																															
RX-8	North America Spec	13B-MSP Standard-Power	SYSTEM SEARCH																															
RX-8	North America Spec	13B-MSP Standard-Power	PCM(Powertrain Control Module)																															
RX-8	North America Spec	13B-MSP Standard-Power	PATS(Passive anti theft system)-Beta																															
RX-8	North America Spec	13B-MSP Standard-Power	ABS(Anti-Lock Brake System)																		V	V												
RX-8	North America Spec	13B-MSP Standard-Power	EPS(Electronic-Controlled Power Steering)																						V									
RX-8	North America Spec	13B-MSP Standard-Power	IC(Instrument Cluster)																															
RX-8	North America Spec	13B-MSP Standard-Power	RCM(Restraint Control Module)																															
RX-8	North America Spec	13B-MSP Standard-Power	RKE(Remote Keyless Entry)																															
RX-8	North America Spec	13B-MSP Standard-Power	TCM(Transmission Control Module)																															
RX-8	North America Spec	13B-MSP Standard-Power	TPM(Tire Pressure Monitor)																															
RX-8	General	13B	SYSTEM SEARCH																															
RX-8	General	13B	PCM(Powertrain Control Module)																															
RX-8	General	13B	PATS(Passive anti theft system)-Beta																															
RX-8	General	13B	ABS(Anti-Lock Brake System)																		V	V												

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
RX-8	General	13B	EPS(Electronic-Controlled Power Steering)																						V									
RX-8	General	13B	IC(Instrument Cluster)																															
RX-8	General	13B	RCM(Restraint Control Module)																															
RX-8	General	13B	RKE(Remote Keyless Entry)																															
RX-8	General	13B	TCM(Transmission Control Module)																															
RX-8	General	13B MSP High Power	SYSTEM SEARCH																															
RX-8	General	13B MSP High Power	PCM(Powertrain Control Module)																															
RX-8	General	13B MSP High Power	PATS(Passive anti theft system)-Beta																															
RX-8	General	13B MSP High Power	ABS(Anti-Lock Brake System)																		V	V												
RX-8	General	13B MSP High Power	EPS(Electronic-Controlled Power Steering)																						V									
RX-8	General	13B MSP High Power	IC(Instrument Cluster)																															
RX-8	General	13B MSP High Power	RCM(Restraint Control Module)																															
RX-8	General	13B MSP High Power	RKE(Remote Keyless Entry)																															
RX-8	General	13B MSP High Power	TCM(Transmission Control Module)																															
RX-8	General	13B MSP Standard Power	SYSTEM SEARCH																															
RX-8	General	13B MSP Standard Power	PCM(Powertrain Control Module)																															
RX-8	General	13B MSP Standard Power	PATS(Passive anti theft system)-Beta																															
RX-8	General	13B MSP Standard Power	ABS(Anti-Lock Brake System)																		V	V												
RX-8	General	13B MSP Standard Power	EPS(Electronic-Controlled Power Steering)																						V									
RX-8	General	13B MSP Standard Power	IC(Instrument Cluster)																															
RX-8	General	13B MSP Standard Power	RCM(Restraint Control Module)																															
RX-8	General	13B MSP Standard Power	RKE(Remote Keyless Entry)																															
RX-8	General	13B MSP Standard Power	TCM(Transmission Control Module)																															
ESCAPETRIBUTE	Up to 2004	SYSTEM SEARCH																																
ESCAPETRIBUTE	Up to 2004	PCM(PowerTrain Control Module)																																
ESCAPETRIBUTE	Up to 2004	Immobilizer																																
ESCAPETRIBUTE	Up to 2004	ABS(Anti-Lock Brake System)																																
ESCAPETRIBUTE	Up to 2004	RCM(Restraint Control Module)																																
ESCAPETRIBUTE	Up to 2004	GEM(Generic Electronic Module)																																
ESCAPETRIBUTE	From 2004	SYSTEM SEARCH																																
ESCAPETRIBUTE	From 2004	PCM(PowerTrain Control Module)															V	V	V															
ESCAPETRIBUTE	From 2004	PATS(Passive anti theft system)																											V	V				
ESCAPETRIBUTE	From 2004	ABS(Anti-Lock Brake System)																																
ESCAPETRIBUTE	From 2004	RCM(Restraint Control Module)																																
ESCAPETRIBUTE	From 2004	IC(Instrument Cluster)																																
ESCAPETRIBUTE	From 2004	GEM(Generic Electronic Module)																																
General(ALL Model)	16PIN CONNECTOR	SYSTEM SEARCH																																
General(ALL Model)	16PIN CONNECTOR	PCM(PowerTrain Control Module)																																
General(ALL Model)	16PIN CONNECTOR	PATS(Passive anti theft system)-Beta																																
General(ALL Model)	16PIN CONNECTOR	TCM(Transmission Control Module)																																
General(ALL Model)	16PIN CONNECTOR	ABS(Anti-Lock Brake System)																																

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
General(ALL Model)	16PIN CONNECTOR	RCM(Restraint Control Module)																																
General(ALL Model)	17PIN CONNECTOR	SYSTEM SEARCH																																
General(ALL Model)	17PIN CONNECTOR	PCM(PowerTrain Control Module)																																
General(ALL Model)	17PIN CONNECTOR	TCM(Transmission Control Module)																																
General(ALL Model)	17PIN CONNECTOR	ABS(Anti-Lock Brake System)																																
General(ALL Model)	17PIN CONNECTOR	RCM(Restraint Control Module)																																
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	PCM(PowerTrain Control Module)																															
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	TCM(Transmission Control Module)																															
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	RCM(Restraint Control Module)																															
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ABS(Anti-Lock Brake System)																															
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ACCM(Air Conditioning Control Module)																															
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	4WS(4 Wheel Steering)																															
General(ALL Model)	17PIN CONNECTOR	Pulse Reading	ICCM(Intelligent Cruise Control Module)																															
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	SYSTEM SEARCH																															
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RKE(Remote Keyless Entry)(WithSKE)																															
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	RKE(Remote Keyless Entry)(WIthout SKE)																															
BETA-ETC	MAZDA 2 EURO	ALL-1.3-1.5-1.4	VSM(Vehicle Security Module)																															
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	SYSTEM SEARCH																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	ASM																													
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	AT																													
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	MT																													
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	PCM(Powertrain Control Module)	PowerShift																													
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	ABS(Anti-Lock Brake System)																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	GEM(Generic Electronic Module)																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	03MY	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	SYSTEM SEARCH																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	PCM(Powertrain Control Module)																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	ABS(Anti-Lock Brake System)																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	GEM(Generic Electronic Module)																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 3 EURO	1.3 ZJ	06MY	RKE(Remote Keyless Entry)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	SYSTEM SEARCH																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 (Low Power without DPF)	ASM	V	V																											

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 (Low Power without DPF)	ALL	V	V																											
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 4 + DPF (High Power with DPF)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	PCM(Powertrain Control Module)-Stage 3(High Power without DPF)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	ABS(Anti-Lock Brake System)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	GEM(Generic Electronic Module)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	03MY	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	SYSTEM SEARCH																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 4(Low Power without DPF)		V	V																											
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 4 + DPF (High Power with DPF)		V	V																											
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	PCM(Powertrain Control Module)-Stage 3(High Power without DPF)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	ABS(Anti-Lock Brake System)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	06MY	RKE(Remote Keyless Entry)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	SYSTEM SEARCH																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	PCM(Powertrain Control Module)		V	V																											
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	ABS(Anti-Lock Brake System)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	BCM/GEM(Body Control Module/Generic Electronic Module)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	FACM(Fuel Additive Control Module)				V	V	V																								
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 3 EURO	1.6 Y6	EURO-06MY	RKE(Remote Keyless Entry)																														
BETA-ETC	MAZDA 3 EURO	1.6 Z6	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 EURO	1.6 Z6	PCM(Powertrain Control Module)																	V														
BETA-ETC	MAZDA 3 EURO	1.6 Z6	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 EURO	1.6 Z6	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 EURO	1.6 Z6	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Z6	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 3 EURO	1.6 Z6	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	SYSTEM SEARCH																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	ASM																													
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	AT																													
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	MT																													
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	PCM(Powertrain Control Module)	PowerShift																													
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	ABS(Anti-Lock Brake System)																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	GEM(Generic Electronic Module)																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	RCM(Restraint Control Module)																														

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BETA-ETC	MAZDA 3 EURO	2.0 LF	03MY	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	SYSTEM SEARCH																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	PCM(Powertrain Control Module)																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	ABS(Anti-Lock Brake System)																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	GEM(Generic Electronic Module)																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 3 EURO	2.0 LF	ALL	RKE(Remote Keyless Entry)																														
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	SYSTEM SEARCH																														
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	PCM(Powertrain Control Module)																														
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	ABS(Anti-Lock Brake System)																														
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	FFH(Fuel Fired Coolant Heating Module)																			V											
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	GEM(Generic Electronic Module)																														
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 3 EURO	2.0 RF_T	RF_T	RKE(Remote Keyless Entry)																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	SYSTEM SEARCH																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	ASM																													
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	AT																													
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	MT																													
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	PCM(Powertrain Control Module)	PowerShift																													
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	ABS(Anti-Lock Brake System)																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	GEM(Generic Electronic Module)																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 3 EURO	2.3 L3	L3	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	SYSTEM SEARCH																														
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	PCM(Powertrain Control Module)																														
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	ABS(Anti-Lock Brake System)																														
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	GEM(Generic Electronic Module)																														
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 3 EURO	2.3 L3_T	L3_T	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	MAZDA GASOLINE ENGINE	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA DIESEL ENGINE	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 ENGINE	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	SYSTEM SEARCH																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	ABS(Anti-Lock Brake System)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	IC(Instrument Cluster)(Include PATS)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.25L	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	SYSTEM SEARCH																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	IC(Instrument Cluster)(Include PATS)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZ_CD DI	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	SYSTEM SEARCH																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	IC(Instrument Cluster)(Include PATS)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.4L MZI	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	SYSTEM SEARCH																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	IC(Instrument Cluster)(Include PATS)																															
BETA-ETC	MAZDA 2 (EURO STG3/4 specs)	1.6MZI	RCM(Restraint Control Module)																															
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	SYSTEM SEARCH																																
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	PCM(Powertrain Control Module)																																
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	ABS(Anti-Lock Brake System)																																
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	EPS(Electronic-Controlled Power Steering)																																
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	IC(Instrument Cluster)																																
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	4x4(4x4 Control Module)																																
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	RCM(Restraint Control Module)																																
BETA-ETC	DEMIO(JPN)/VERISA(JPN)/MAZDA 2 (Gerneral)	RKE(Remote Keyless Entry)																																
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	SYSTEM SEARCH																															
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	PCM(Powertrain Control Module)																															
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	ABS(Anti-Lock Brake System)																															
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	IC(Instrument Cluster)																															
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	RCM(Restraint Control Module)																															
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	RKE(Remote Keyless Entry)																															
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	VSM(Vehicle Security Module)																															
BETA-ETC	DEMIO(JPN)/MAZDA2(General)	TEST-Essential(gasoline)	TCM(Transmission Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	SYSTEM SEARCH																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	PCM(Powertrain Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	ABS(Anti-Lock Brake System)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	EPS(Electronic-Controlled Power Steering)																														

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	GEM(Generic Electronic Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	RCM(Restraint Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2003MY	IC(Instrument Cluster)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	SYSTEM SEARCH																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	PCM(Powertrain Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	ABS(Anti-Lock Brake System)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	IC(Instrument Cluster)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	1.5 ZY	2006MY	RKE(Remote Keyless Entry)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	SYSTEM SEARCH																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	PCM(Powertrain Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	ABS(Anti-Lock Brake System)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2003MY	IC(Instrument Cluster)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	SYSTEM SEARCH																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	PCM(Powertrain Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	ABS(Anti-Lock Brake System)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	IC(Instrument Cluster)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2006MY	RKE(Remote Keyless Entry)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	SYSTEM SEARCH																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	PCM(Powertrain Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	TCM(Transmission Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	ABS(Anti-Lock Brake System)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	RCM(Restraint Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	IC(Instrument Cluster)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	BCM/GEM(Body Control Module/Generic Electronic Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.0 LF	2011MY	MID(Multi-Information Display)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	SYSTEM SEARCH																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	PCM(Powertrain Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	ABS(Anti-Lock Brake System)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	BCM/GEM(Body Control Module/Generic Electronic Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	RCM(Restraint Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	IC(Instrument Cluster)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	MID(Multi-Information Display)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.2 R2_T	2007 ~	EATC(Electronic Automatic Temperature Control)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	SYSTEM SEARCH																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	PCM(Powertrain Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	ABS(Anti-Lock Brake System)																														

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2003MY	IC(Instrument Cluster)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	SYSTEM SEARCH																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	PCM(Powertrain Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	ABS(Anti-Lock Brake System)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	EPS(Electronic-Controlled Power Steering)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	IC(Instrument Cluster)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	RKE(Remote Keyless Entry)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3	2006MY	TCM(Transmission Control Module)																														
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	SYSTEM SEARCH																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	PCM(Powertrain Control Module)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	ABS(Anti-Lock Brake System)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	IC(Instrument Cluster)																															
BETA-ETC	AXELA/MAZDA 3 (JPN/General specs)	2.3 L3_T	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 (North America/General)	SYSTEM SEARCH																																
BETA-ETC	MAZDA 3 (North America/General)	PCM(Powertrain Control Module)																																
BETA-ETC	MAZDA 3 (North America/General)	ABS(Anti-Lock Brake System)																																
BETA-ETC	MAZDA 3 (North America/General)	IC(Instrument Cluster)																																
BETA-ETC	MAZDA 3 (North America/General)	TPM(Tire Pressure Monitor)																																
BETA-ETC	MAZDA 3 (China/General)	1.6L	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 (China/General)	1.6L	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 (China/General)	1.6L	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 (China/General)	1.6L	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 (China/General)	1.6L	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 3 (China/General)	2.0L	SYSTEM SEARCH																															
BETA-ETC	MAZDA 3 (China/General)	2.0L	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 3 (China/General)	2.0L	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 3 (China/General)	2.0L	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 3 (China/General)	2.0L	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 3 (China/General)	2.0L	RKE(Remote Keyless Entry)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	SYSTEM SEARCH																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	PCM(Powertrain Control Module)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	ABS(Anti-Lock Brake System)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	IC(Instrument Cluster)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	GEM(Generic Electronic Module)											V																				
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RCM(Restraint Control Module)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	LPSDM(Left Power Sliding Door Module)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RPSDM(Right Power Sliding Door Module)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	TCM(Transmission Control Module)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.0L LF	RKE(Remote Keyless Entry)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	SYSTEM SEARCH																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	PCM(Powertrain Control Module)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	ABS(Anti-Lock Brake System)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	IC(Instrument Cluster)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	GEM(Generic Electronic Module)												V																			
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RCM(Restraint Control Module)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	LPSDM(Left Power Sliding Door Module)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RPSDM(Right Power Sliding Door Module)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	TCM(Transmission Control Module)																															
BETA-ETC	PREMACY/MAZDA 5 (JPN/General specs)	2.3L L3	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	SYSTEM SEARCH																															
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	EPS(Electronic-Controlled Power Steering)																															
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 5 (North America specs)	2.3L L3	TPM(Tire Pressure Monitor)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	SYSTEM SEARCH																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	PCM(Powertrain Control Module)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	ABS(Anti-Lock Brake System)																	V	V												
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	LHID(Left High Intensity Discharge Lamp)																				V										
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	RHID(Right High Intensity Discharge Lamp)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2002 MY	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	SYSTEM SEARCH																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	PCM(Powertrain Control Module)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	ABS(Anti-Lock Brake System)																	V	V												
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	GEM(Generic Electronic Module)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	LHID(Left High Intensity Discharge Lamp)																				V										
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RHID(Right High Intensity Discharge Lamp)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	1.8 L8	2005 MY	RKE(Remote Keyless Entry)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	SYSTEM SEARCH																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	PCM(Powertrain Control Module)	ALL																													
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	PCM(Powertrain Control Module)	MT																													
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	ABS(Anti-Lock Brake System)																	V	V												
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	LHID(Left High Intensity Discharge Lamp)																				V										

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	RHID(Right High Intensity Discharge Lamp)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2002MY	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	SYSTEM SEARCH																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	PCM(Powertrain Control Module)	ALL																													
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	PCM(Powertrain Control Module)	MT																													
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	ABS(Anti-Lock Brake System)																V	V													
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	GEM(Generic Electronic Module)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	LHID(Left High Intensity Discharge Lamp)																			V											
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RHID(Right High Intensity Discharge Lamp)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	RKE(Remote Keyless Entry)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 LF	2005MY	TCM(Transmission Control Module)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	ABS(Anti-Lock Brake System)																	V	V													
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	GEM(Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	LHID(Left High Intensity Discharge Lamp)																				V											
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.0 RF_T	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	SYSTEM SEARCH																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	PCM(Powertrain Control Module)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	ABS(Anti-Lock Brake System)																V	V													
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	GEM(Generic Electronic Module)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	IC(Instrument Cluster)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	LHID(Left High Intensity Discharge Lamp)																			V											
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RHID(Right High Intensity Discharge Lamp)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RCM(Restraint Control Module)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	RKE(Remote Keyless Entry)																														
BETA-ETC	MAZDA 6 (Euro STG3/4 General)	2.3 L3 L3_T	L3	TCM(Transmission Control Module)																														
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	SYSTEM SEARCH																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	PCM(Powertrain Control Module)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	ABS(Anti-Lock Brake System)																	V	V													
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	GEM(Generic Electronic Module)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	IC(Instrument Cluster)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	LHID(Left High Intensity Discharge Lamp)																				V											
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RCM(Restraint Control Module)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	RKE(Remote Keyless Entry)																												V	V		
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.0 LF	TCM(Transmission Control Module)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	SYSTEM SEARCH																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	PCM(Powertrain Control Module)	ALL																														
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	PCM(Powertrain Control Module)	MT																														
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	ABS(Anti-Lock Brake System)																		V	V												
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	GEM(Generic Electronic Module)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	LHID(Left High Intensity Discharge Lamp)																					V										
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RHID(Right High Intensity Discharge Lamp)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	IC(Instrument Cluster)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RCM(Restraint Control Module)																															
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	RKE(Remote Keyless Entry)																												V	V		
BETA-ETC	ATENZA(JPN)_MAZDA 6 (Gerneral)	2.3 L3 / L3_T	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	EATC(Electronic Automatic Temperature Control)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	EPS(Electronic-Controlled Power Steering)																						V									
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	1.8 L8	RVM(Rear Vehicle Monitoring)-Beta Test																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	EATC(Electronic Automatic Temperature Control)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	EPS(Electronic-Controlled Power Steering)																						V									
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 LF	RVM(Rear Vehicle Monitoring)-Beta Test																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	EATC(Electronic Automatic Temperature Control)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	EPS(Electronic-Controlled Power Steering)																						V									
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	IC(Instrument Cluster)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.0 RF_T	RVM(Rear Vehicle Monitoring)-Beta Test																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	EATC(Electronic Automatic Temperature Control)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	FFH(Fuel Fired Coolant Heating Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	EPS(Electronic-Controlled Power Steering)																					V										
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.2 R2_T Diesel	RVM(Rear Vehicle Monitoring)-Beta Test																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	ABS(Anti-Lock Brake System)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	BCM/GEM(Body Control Module/Generic Electronic Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	EATC(Electronic Automatic Temperature Control)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	EPS(Electronic-Controlled Power Steering)																					V										
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RCM(Restraint Control Module)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RKE(Remote Keyless Entry)																															
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	TCM(Transmission Control Module)																														V	
BETA-ETC	MAZDA 6 (GH/Before Facelift)	2.5 L5	RVM(Rear Vehicle Monitoring)-Beta Test																															
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	PCM(Powertrain Control Module)-ALL																															
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 6 (North America/General)	2.3 L3	TPM(Tire Pressure Monitor)																															
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	SYSTEM SEARCH																															
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	PCM(Powertrain Control Module)																															
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	IC(Instrument Cluster)																															
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	TCM(Transmission Control Module)																															
BETA-ETC	MAZDA 6 (North America/General)	3.0 AJ	TPM(Tire Pressure Monitor)																															
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	SYSTEM SEARCH																															
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	PCM(Powertrain Control Module)																															
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	ABS(Anti-Lock Brake System)																															
BETA-ETC	MPV (JPN/General)	2.0L RF_T(Europe/General)	FFH(Fuel Fired Coolant Heating Module)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	SYSTEM SEARCH																															
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	PCM(Powertrain Control Module)														V	V	V															
BETA-ETC	MPV (JPN/General)	2.3L L3(Europe/General)	ABS(Anti-Lock Brake System)																															
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	SYSTEM SEARCH																															
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	PCM(Powertrain Control Module)														V	V	V															
BETA-ETC	MPV (JPN/General)	2.3L L3(Japan/General)	ABS(Anti-Lock Brake System)																															
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	SYSTEM SEARCH																															
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	PCM(Powertrain Control Module)														V	V	V															
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	ABS(Anti-Lock Brake System)																															
BETA-ETC	MPV (JPN/General)	3.0L AJ(Japan/General)	TCM(Transmission Control Module)																															
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	SYSTEM SEARCH																															
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	PCM(Powertrain Control Module)																															
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	ABS(Anti-Lock Brake System)																															
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	RCM(Restraint Control Module)																															
BETA-ETC	MPV (JPN/General)	3.0L AJ(North America/General)	TCM(Transmission Control Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	SYSTEM SEARCH																															
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	PCM(Powertrain Control Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	ABS(Anti-Lock Brake System)																		V	V												
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	GEM(Generic Electronic Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	HCM(Headlamp Control Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	ICCM(Intelligent Cruise Control Module)-Beta Test																															
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	IC(Instrument Cluster)																															
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	LTM(Liftgate/Trunk Module)-Beta Test																															
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	RCM(Restraint Control Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	RKE(Remote Keyless Entry)																															
BETA-ETC	MPV (JPN/General)	2.3L L3 MPV/MAZDA 8	TCM(Transmission Control Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	SYSTEM SEARCH																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	PCM(Powertrain Control Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	ABS(Anti-Lock Brake System)																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	GEM(Generic Electronic Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	HCM(Headlamp Control Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	ICCM(Intelligent Cruise Control Module)-Beta Test																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	IC(Instrument Cluster)																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LTM(Liftgate/Trunk Module)-Beta Test																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RCM(Restraint Control Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RKE(Remote Keyless Entry)																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	TCM(Transmission Control Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LCM(Lighting Control Module)-Beta Test											V																				
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	4x4(4x4 Control Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	LPSDM(Left Power Sliding Door Module)																															
BETA-ETC	MPV (JPN/General)	2.3L L3_T MPV/MAZDA 8	RPSDM(Right Power Sliding Door Module)																															

Vehicle	Capacity	System 1	System 2	System 3	System 4	Reset Charge Air Cooler Bypass Vlave Position Offset	Reset Engine Coolant FAN Learning	New Fuel Additive Control Module	Refill the Fuel Additive Tank	System Prime	BCM GEM Installation	Personality	Interior Lighting	Washer/Wiper	Rain Sensor Reset	Wheel Speed Sensor Test	IDLE Air Control System Test	TR Sensor Test(Normal)	TR Sensor Test(Sport-type Automatic)	Reset the frequency of the power relay activations	Yaw Rate Sensor(Only With DSC)	Lateral Acceleration Sensor(Only With DSC)	FFH Unlock Utility	Key On Engine Off Self Test	Neutral Position Setting	Fuel Pump PCM Reset	Injector PCM Reset	MAF Sensor PCM Reset	Ignition key code erase and program(Beta)	Program additional ignition key(Beta)	Program Additional Card Key	Card Key Code Erase and Program	Neutral Position Learning	Vehicle Data Log Capture
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	SYSTEM SEARCH																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	PCM(Powertrain Control Module)																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	ABS(Anti-Lock Brake System)																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	IC(Instrument Cluster)																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	1.8L L8	TCM(Transmission Control Module)																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	SYSTEM SEARCH																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	2005~																														
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	PCM(Powertrain Control Module)	~2005																														
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	ABS(Anti-Lock Brake System)																															
BETA-ETC	BONGO/BRAWNY/SPECTRON	2.0L RF_T	TCM(Transmission Control Module)																															
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	SYSTEM SEARCH																															
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	PCM(Powertrain Control Module)																															
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	ABS(Anti-Lock Brake System)																															
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	RCM(Restraint Control Module)																															
BETA-ETC	EVEREST/ENDEAVOUR	2.5L WL-CD	TCM(Transmission Control Module)																															
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	SYSTEM SEARCH																															
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	PCM(Powertrain Control Module)																															
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	ABS(Anti-Lock Brake System)																															
BETA-ETC	EVEREST/ENDEAVOUR	3.0L WE-CD	TCM(Transmission Control Module)																															
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	SYSTEM SEARCH																															
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	PCM(Powertrain Control Module)																															
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	ABS(Anti-Lock Brake System)																															
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	GEM(Generic Electronic Module)																															
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	IC(Instrument Cluster)																															
BETA-ETC	ESCAPE/TRIBUTE	2.3L L3	RCM(Restraint Control Module)																															
BETA-ETC	TITAN DASH	2.0L RF_T	SYSTEM SEARCH																															
BETA-ETC	TITAN DASH	2.0L RF_T	PCM(Powertrain Control Module)																															
BETA-ETC	TITAN DASH	2.0L RF_T	TCM(Transmission Control Module)																															
BETA-ETC	PATS(Passive anti theft system)																																	
BETA-ETC	Vehicle Log Capture																																	V

Series	Model	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	System Identification	Service (CBS) Reset	Register Battery Replacement	Reset All Adaptation Values	Teach In Components	Rain sensor initialisation	Sensitivity level
MINI	MINI ONE/COOPER 2001-2006[R50]	Drive	DME (Digital Motor Electronics)	V	V	V	V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Drive	EGS (Electronic transmission management)	V	V	V	V			V	V		
MINI	MINI ONE/COOPER 2001-2006[R50]	Drive	EWS(Electronic immobilizer)	V	V		V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Chassis	ABS/ASC/DSC(Dynamic Stability Control)	V	V	V	V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Chassis	EHPS(Electro-hydraulic steering assistance)	V	V	V	V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Chassis	LEW(Steering angle sensor)	V	V		V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Body	AIC/RLS(Automatic Interval Control/Rain Light Sensor)	V	V		V					V	V
MINI	MINI ONE/COOPER 2001-2006[R50]	Body	CDC(CD Changer)	V		V	V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Body	CVM (Soft top module)	V	V		V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Body	KOM(Instrument cluster)	V	V	V	V	V					
MINI	MINI ONE/COOPER 2001-2006[R50]	Body	KOM2(Additional instruments)				V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Body	MFL(Multi-function steering wheel)	V	V	V	V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Body	MRS (Multiple restraint system)	V	V		V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Body	PDC (Park Distance Control)	V	V	V	V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Body	RAD (Radio)	V	V	V	V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Body	SHD (Sliding/tilting sunroof)	V	V	V	V						
MINI	MINI ONE/COOPER 2001-2006[R50]	Body	ZKE(Central body electronics BC1)	V	V	V	V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Drive	DME (Digital Motor Electronics)	V	V	V	V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Drive	EGS (Electronic transmission management)	V	V	V	V			V	V		
MINI	MINI CONVERTIBLE 2004-2008[R52]	Drive	EWS(Electronic immobilizer)	V	V		V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Chassis	ABS/ASC/DSC(Dynamic Stability Control)	V	V	V	V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Chassis	EHPS(Electro-hydraulic steering assistance)	V	V	V	V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Chassis	LEW(Steering angle sensor)	V	V		V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Body	AIC/RLS(Automatic Interval Control/Rain Light Sensor)	V	V		V					V	V
MINI	MINI CONVERTIBLE 2004-2008[R52]	Body	CDC(CD Changer)	V		V	V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Body	CVM (Soft top module)	V	V		V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Body	KOM(Instrument cluster)	V	V	V	V	V					
MINI	MINI CONVERTIBLE 2004-2008[R52]	Body	KOM2(Additional instruments)				V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Body	MFL(Multi-function steering wheel)	V	V	V	V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Body	MRS (Multiple restraint system)	V	V		V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Body	PDC (Park Distance Control)	V	V	V	V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Body	RAD (Radio)	V	V	V	V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Body	SHD (Sliding/tilting sunroof)	V	V	V	V						
MINI	MINI CONVERTIBLE 2004-2008[R52]	Body	ZKE(Central body electronics BC1)	V	V	V	V						
MINI	MINI COOPER S 2001-2006[R53]	Drive	DME (Digital Motor Electronics)	V	V	V	V						
MINI	MINI COOPER S 2001-2006[R53]	Drive	EGS (Electronic transmission management)	V	V	V	V			V	V		
MINI	MINI COOPER S 2001-2006[R53]	Drive	EWS(Electronic immobilizer)	V	V		V						
MINI	MINI COOPER S 2001-2006[R53]	Chassis	ABS/ASC/DSC(Dynamic Stability Control)	V	V	V	V						
MINI	MINI COOPER S 2001-2006[R53]	Chassis	EHPS(Electro-hydraulic steering assistance)	V	V	V	V						
MINI	MINI COOPER S 2001-2006[R53]	Chassis	LEW(Steering angle sensor)	V	V		V						
MINI	MINI COOPER S 2001-2006[R53]	Body	AIC/RLS(Automatic Interval Control/Rain Light Sensor)	V	V		V					V	V
MINI	MINI COOPER S 2001-2006[R53]	Body	CDC(CD Changer)	V		V	V						

Series	Model	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	System Identification	Service (CBS) Reset	Register Battery Replacement	Reset All Adaptation Values	Teach In Components	Rain sensor initialisation	Sensitivity level
MINI	MINI COOPER S 2001-2006[R53]	Body	CVM (Soft top module)	V	V		V						
MINI	MINI COOPER S 2001-2006[R53]	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V						
MINI	MINI COOPER S 2001-2006[R53]	Body	KOM(Instrument cluster)	V	V	V	V	V					
MINI	MINI COOPER S 2001-2006[R53]	Body	KOM2(Additional instruments)				V						
MINI	MINI COOPER S 2001-2006[R53]	Body	MFL(Multi-function steering wheel)	V	V	V	V						
MINI	MINI COOPER S 2001-2006[R53]	Body	MRS (Multiple restraint system)	V	V		V						
MINI	MINI COOPER S 2001-2006[R53]	Body	PDC (Park Distance Control)	V	V	V	V						
MINI	MINI COOPER S 2001-2006[R53]	Body	RAD (Radio)	V	V	V	V						
MINI	MINI COOPER S 2001-2006[R53]	Body	SHD (Sliding/tilting sunroof)	V	V	V	V						
MINI	MINI COOPER S 2001-2006[R53]	Body	ZKE(Central body electronics BC1)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Maintenance	CBS Reset										
MINI	MINI CLUBMAN [R55]	Drive	CAS (Car Access System)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Drive	DME (Digital Motor Electronics)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Drive	EGS (Electronic transmission management)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Chassis	DSC (Dynamic stability control)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Chassis	EPS (Electromechanical power steering)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	ACSM (Crash Safety Module)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	CHAMP (Central headunit and Multimedia Platform))	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	CHAMP-GW (Gateway)	V			V						
MINI	MINI CLUBMAN [R55]	Body	CID (Central Information Display)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	FRM (Footwell module)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	JBE (Junction-box electronics)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	KOMBI (Instrument cluster)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	MJOY (MINI joystick)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	PDC (Park Distance Control)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	RAD2 (BMW professional radio)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	RAD2-GW (Gateway)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	SHD (Sliding/tilting sunroof)	V	V	V	V						
MINI	MINI CLUBMAN [R55]	Body	SZL (Switch center, steering column)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Maintenance	CBS Reset					V					
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Drive	CAS (Car Access System)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Drive	DME (Digital Motor Electronics)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Drive	EGS (Electronic transmission management)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Chassis	DSC (Dynamic stability control)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Chassis	EPS (Electromechanical power steering)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	ACSM (Crash Safety Module)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	CHAMP (Central headunit and Multimedia Platform))	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	CHAMP-GW (Gateway)	V			V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	CID (Central Information Display)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	FRM (Footwell module)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	JBE (Junction-box electronics)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	KOMBI (Instrument cluster)	V	V	V	V						

Series	Model	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	System Identification	Service (CBS) Reset	Register Battery Replacement	Reset All Adaptation Values	Teach In Components	Rain sensor initialisation	Sensitivity level
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	MJOY (MINI joystick)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	PDC (Park Distance Control)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	RAD2 (BMW professional radio)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	RAD2-GW (Gateway)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	SHD (Sliding/tilting sunroof)	V	V	V	V						
MINI	MINI ONE/COOPER S/D 2006-present[R56]	Body	SZL (Switch center, steering column)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Maintenance	CBS Reset					V					
MINI	MINI Cooper CONVERTIBLE (R57)	Drive	CAS (Car Access System)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Drive	DME (Digital Motor Electronics)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Drive	EGS (Electronic transmission management)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Chassis	DSC (Dynamic stability control)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Chassis	EPS (Electromechanical power steering)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	ACSM (Crash Safety Module)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	CHAMP (Central headunit and Multimedia Platform)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	CHAMP-GW (Gateway)	V			V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	CID (Central Information Display)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	CVM (Soft top module)	V	V		V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	FRM (Footwell module)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	JBE (Junction-box electronics)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	KOMBI (Instrument cluster)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	MJOY (MINI joystick)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	PDC (Park Distance Control)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	RAD2 (BMW professional radio)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	RAD2-GW (Gateway)	V	V	V	V						
MINI	MINI Cooper CONVERTIBLE (R57)	Body	SZL (Switch center, steering column)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Maintenance	CBS Reset					V					
MINI	MINI Cooper ROADSTER (R58)	Drive	CAS (Car Access System)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Drive	DME (Digital Motor Electronics)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Drive	EGS (Electronic transmission management)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Chassis	DSC (Dynamic stability control)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Chassis	EPS (Electromechanical power steering)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Body	ACSM (Crash Safety Module)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Body	CHAMP (Central headunit and Multimedia Platform)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Body	CHAMP-GW (Gateway)	V			V						
MINI	MINI Cooper ROADSTER (R58)	Body	CID (Central Information Display)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Body	FRM (Footwell module)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Body	JBE (Junction-box electronics)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Body	KOMBI (Instrument cluster)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Body	MJOY (MINI joystick)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Body	PDC (Park Distance Control)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Body	RAD2 (BMW professional radio)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Body	RAD2-GW (Gateway)	V	V	V	V						

Series	Model	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	System Identification	Service (CBS) Reset	Register Battery Replacement	Reset All Adaptation Values	Teach In Components	Rain sensor initialisation	Sensitivity level
MINI	MINI Cooper ROADSTER (R58)	Body	SHD (Sliding/tilting sunroof)	V	V	V	V						
MINI	MINI Cooper ROADSTER (R58)	Body	SZL (Switch center, steering column)	V	V	V	V						
MINI	Countryman (R60)	Maintenance	CBS Reset					V					
MINI	Countryman (R60)	Drive	CAS (Car Access System)	V	V	V	V						
MINI	Countryman (R60)	Drive	DME (Digital Motor Electronics)	V	V	V	V						
MINI	Countryman (R60)	Drive	EGS (Electronic transmission management)	V	V	V	V						
MINI	Countryman (R60)	Chassis	DSC (Dynamic stability control)	V	V	V	V						
MINI	Countryman (R60)	Chassis	EPS (Electromechanical power steering)	V	V	V	V						
MINI	Countryman (R60)	Chassis	RDC (Tyre Pressure Monitor)	V	V	V	V						
MINI	Countryman (R60)	Body	ACSM (Crash Safety Module)	V	V	V	V						
MINI	Countryman (R60)	Body	CA (Comfort Access)	V	V	V	V						
MINI	Countryman (R60)	Body	FRM (Footwell module)	V	V	V	V						
MINI	Countryman (R60)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V						
MINI	Countryman (R60)	Body	KOMBI (Instrument cluster)	V	V	V	V						
MINI	Countryman (R60)	Body	JBE (Junction-box electronics)	V	V	V	V						
MINI	Countryman (R60)	Body	PDC (Park Distance Control)	V	V	V	V						
MINI	Countryman (R60)	Body	RAD (Radio)	V	V	V	V						
MINI	Countryman (R60)	Body	RAD2 (BMW professional radio)	V	V	V	V						
MINI	Countryman (R60)	Body	RAD2-GW (Gateway)	V	V	V	V						
MINI	Countryman (R60)	Body	SDARS (Satellite tuner (US))	V	V	V	V						
MINI	Countryman (R60)	Body	SHD (Sliding/tilting sunroof)	V	V	V	V						
MINI	Countryman (R60)	Body	SZL (Switch center / steering column)	V	V	V	V						
MINI	Cooper (F55 / F56)	Special function	CBS Reset					V					
MINI	Cooper (F55 / F56)	Special function	Register battery replacement						V				
MINI	Cooper (F55 / F56)	Drive	DME (Digital Engine Electronics)	V	V	V	V						
MINI	Cooper (F55 / F56)	Drive	EGS (Electronic transmission management)	V	V	V	V						
MINI	Cooper (F55 / F56)	Chassis	DSC (Dynamic stability control)	V	V	V	V						
MINI	Cooper (F55 / F56)	Chassis	EPS (Electromechanical power steering)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	ACSM (Crash Safety Module)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	AMP (Hi-Fi amplifier)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	ASD (Active Sound Design)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	BDC (Body Domain Controller)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	CON (Controller)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	FLEL (Frontal Light Electronics Left)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	FLER (Frontal Light Electronics Right)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	FZD (Function center, roof)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	HU-H	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	IHKA (Integrated automatic heating / air conditioning system)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	KOMBI (Instrument panel control unit)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	PMA (Parking manoeuvring assistant)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	RAD (Radio)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	TBX (Touchbox)	V	V	V	V						
MINI	Cooper (F55 / F56)	Body	ZGM (Central Gateway Module)	V			V						

Area	Vehicle	System	Diagnostic Trouble Code	Data List	Actuator Test	ECU Information	Reset	Test	Learning	Initialization	Injector ID Code Resistration	DPF Regeneration	VIN Writing	Coding	CVT Oil Degradation level	Emission Gas Mode	Sensor calibration	Valve Pressure Learning	Yaw rate sensor type reset	Air bleeding	Customization	Customization Reset	Theft alarm	Service remainder reset	Head lamp Auto leveling Diag mode	SAS Calibration	Keyless ID Registration	Keyless Reception Check	Key Registration	Additional Key Reg. (using key)	Steering lock unit Reg	Engine Key Code Reg.	Engine Key Code Registration, VIN Writing	Zero Calibration & System Test	HS initial position Clear	HS initial position Learning	Forced power supply output	Forced power supply output (stop)	TPMS ID Registration	TPMS ID Check
International	Model Year (From 2005MY)	SYSTEM SEARCH																																							
International	Model Year (From 2005MY)	MPI / GDI / DIESEL	V	V	V	V	V	V	V	V	V	V	V																												
International	Model Year (From 2005MY)	AS & G	V	V		V																																			
International	Model Year (From 2005MY)	KOS / IMMO / Keyless	V	V	V	V		V					V														V	V	V	V	V	V	V								
International	Model Year (From 2005MY)	ELC-AT / CVT / TC-SST	V	V	V	V	V						V	V	V																										
International	Model Year (From 2005MY)	TCL (Traction Control Logic)	V	V	V	V																																			
International	Model Year (From 2005MY)	CRUISE CONTROL		V		V																																			
International	Model Year (From 2005MY)	SS4 II (Super Select 4WD II) / ES4	V	V	V	V																																			
International	Model Year (From 2005MY)	Shift Lever	V	V	V	V																																			
International	Model Year (From 2005MY)	4WS / Electric Power Steering	V	V	V	V																																			
International	Model Year (From 2005MY)	ABS/ASC/ASTC/WSS	V	V	V	V										V	V	V	V																						
International	Model Year (From 2005MY)	HBB (Hydraulic Brake Booster)	V	V		V																																			
International	Model Year (From 2005MY)	AYC(Active Yaw Control)/ACD(Active Central Differential)	V	V	V	V		V									V			V																					
International	Model Year (From 2005MY)	SRS-AIR BAG	V	V	V	V				V																															
International	Model Year (From 2005MY)	Air Conditioner	V	V	V	V																																			
International	Model Year (From 2005MY)	Lane Keep	V	V	V	V	V		V																																
International	Model Year (From 2005MY)	ETACS (Electronic Time and Alarm Control System)	V	V	V	V							V	V							V	V	V				V	V							V	V					
International	Model Year (From 2005MY)	TPMS	V	V		V																																	V	V
International	Model Year (From 2005MY)	Meter	V	V	V	V		V																V	V																
International	Model Year (From 2005MY)	Display	V	V	V	V																																			
International	Model Year (From 2005MY)	RHT / Topstack	V	V	V	V		V	V																																
International	Model Year (From 2005MY)	Steering Angle Sensor	V			V																				V															
International	Model Year (From 2005MY)	4WD / AWC	V	V		V	V	V																																	
International	Model Year (From 2005MY)	AND	V			V																																			
International	Model Year (From 2005MY)	AUDIO	V	V		V																																			
International	Model Year (From 2005MY)	HFM	V	V	V	V																																			
International	Model Year (From 2005MY)	AFS / ACL / Leveling	V	V	V	V																													V	V					
International	Model Year (From 2005MY)	Power Gate	V	V	V	V																																			
International	Model Year (From 2005MY)	OSS (One touch Start System)	V	V	V	V																															V	V	V	V
International	Model Year (From 2005MY)	CORNER SENSOR/BACK SENSOR	V	V		V																																			
International	Model Year (From 2005MY)	ACC/FCM	V	V		V	V		V																																
International	Model Year (From 2005MY)	OCM	V	V		V																												V							
International	Model Year (From 2005MY)	CAN / LIN / SWS converter	V	V		V	V														V																				
International	Model Year (Up to 2004MY)	SYSTEM SEARCH																																							
International	Model Year (Up to 2004MY)	MPI / GDI / DIESEL	V	V	V	V																																			
International	Model Year (Up to 2004MY)	IMMOBILIZER	V	V		V																							V												
International	Model Year (Up to 2004MY)	ELE-AT / CVT	V	V	V	V																																			
International	Model Year (Up to 2004MY)	SS4 II (Super Select 4WD II)	V	V	V	V																																			
International	Model Year (Up to 2004MY)	TCL (Traction Control Logic)	V	V	V	V																																			
International	Model Year (Up to 2004MY)	ECS (Electronic Contol Suspension)	V	V	V	V																																			
International	Model Year (Up to 2004MY)	ABS / ASC / ASTC	V	V	V	V																																			
International	Model Year (Up to 2004MY)	HBB (Hydraulic Brake Booster)	V	V		V																																			
International	Model Year (Up to 2004MY)	AYC(Active Yaw Control)/ACD(Active Central Differential)	V	V	V	V																																			
International	Model Year (Up to 2004MY)	SRS-AIR BAG	V	V		V																																			
International	Model Year (Up to 2004MY)	Air Conditioner	V	V	V	V																																			
International	OUTLANDER-PHEV	SYSTEM SEARCH																																							
International	OUTLANDER-PHEV	MPI / GDI / DIESEL	V	V	V	V	V					V																													
International	OUTLANDER-PHEV	4WS / Electric Power Steering	V	V	V	V																																			

Area	Vehicle	System	Diagnostic Trouble Code	Data List	Actuator Test	ECU Information	Reset	Test	Learning	Initialization	Injector ID Code Resistration	DPF Regeneration	VIN Writing	Coding	CVT Oil Degradation level	Emission Gas Mode	Sensor calibration	Valve Pressure Learning	Yaw rate sensor type reset	Air bleeding	Customization	Customization Reset	Theft alarm	Service remainder reset	Head lamp Auto leveling Diag mode	SAS Calibration	Keyless ID Registration	Keyless Reception Check	Key Registration	Additional Key Reg. (using key)	Steering lock unit Reg	Engine Key Code Reg.	Engine Key Code Registration, VIN Writing	Zero Calibration & System Test	HS initial position Clear	HS initial position Learning	Forced power supply output	Forced power supply output (stop)	TPMS ID Registration	TPMS ID Check
International	OUTLANDER-PHEV	ABS/ASC/ASTC/WSS	V	V	V	V										V	V																							
International	OUTLANDER-PHEV	SRS-AIR BAG	V	V	V	V				V																														
International	OUTLANDER-PHEV	Air Conditioner	V	V	V	V																																		
International	OUTLANDER-PHEV	Lane Keep	V	V	V	V	V		V																															
International	OUTLANDER-PHEV	ETACS (Electronic Time and Alarm Control System)	V	V	V	V							V	V							V	V	V				V	V							V	V				
International	OUTLANDER-PHEV	TPMS	V	V		V																																	V	V
International	OUTLANDER-PHEV	Meter	V	V	V	V		V																V	V															
International	OUTLANDER-PHEV	Steering Angle Sensor	V			V																				V														
International	OUTLANDER-PHEV	AND	V			V																																		
International	OUTLANDER-PHEV	AUDIO	V	V		V																																		
International	OUTLANDER-PHEV	Power Gate	V	V	V	V																																		
International	OUTLANDER-PHEV	KOS / IMMO / Keyless	V	V	V	V		V					V														V	V	V	V	V	V	V							
International	OUTLANDER-PHEV	OSS (One touch Start System)	V	V	V	V																															V	V	V	V
International	OUTLANDER-PHEV	CORNER SENSOR/BACK SENSOR	V	V		V																																		
International	OUTLANDER-PHEV	ACC/FCM	V	V		V	V		V																															
International	OUTLANDER-PHEV	PHEV	V	V	V	V																																		
International	OUTLANDER-PHEV	EV/MiEV Remote System	V	V	V	V																																		
International	OUTLANDER-PHEV	OBC (On Board Charger)	V	V	V	V																																		
International	OUTLANDER-PHEV	BMU (Battery Monitoring Unit)	V	V	V	V																																		
International	OUTLANDER-PHEV	Compressor	V	V		V																																		
International	OUTLANDER-PHEV	F-MCU	V	V		V																																		
International	OUTLANDER-PHEV	GCU	V	V	V	V																																		
International	OUTLANDER-PHEV	R-MCU	V	V		V																																		
International	OUTLANDER-PHEV	P LOCK		V		V																																		
International	OUTLANDER-PHEV	CMU1 (Cell Monitor Unit)		V		V																																		
International	OUTLANDER-PHEV	CMU2		V		V																																		
International	OUTLANDER-PHEV	CMU3		V		V																																		
International	OUTLANDER-PHEV	CMU4		V		V																																		
International	OUTLANDER-PHEV	CMU5		V		V																																		
International	OUTLANDER-PHEV	CMU7		V		V																																		
International	OUTLANDER-PHEV	CMU8		V		V																																		
International	OUTLANDER-PHEV	CMU9		V		V																																		
International	OUTLANDER-PHEV	CMU10		V		V																																		
International	OUTLANDER-PHEV	CMU11		V		V																																		
International	i	SYSTEM SEARCH																																						
International	i	MPI / GDI / DIESEL	V	V	V	V	V					V																												
International	i	IMMOBILIZER	V	V		V																							V		V		V							
International	i	ELC-AT / CVT / TC-SST	V	V	V	V	V																																	
International	i	4WS / Electric Power Steering	V	V	V	V																																		
International	i	ABS/ASC/ASTC/WSS	V	V	V	V										V	V																							
International	i	SRS Airbag	V	V	V																																			
International	i	Air Conditioner	V	V	V	V																																		
International	i	ETACS(Electronic Time and Alarm Control System)	V	V	V	V	V							V							V	V					V	V												
International	i	Meter	V	V	V	V																		V																
International	i	Steering Angle Sensor	V			V																				V														
International	eK	SYSTEM SEARCH																																						
International	eK	MPI / GDI / DIESEL	V	V	V	V	V					V																												
International	eK	OSS (One touch Start System)	V	V		V		V					V																V			V	V				V	V		

Area	Vehicle	System	Diagnostic Trouble Code	Data List	Actuator Test	ECU Information	Reset	Test	Learning	Initialization	Injector ID Code Resistration	DPF Regeneration	VIN Writing	Coding	CVT Oil Degradation level	Emission Gas Mode	Sensor calibration	Valve Pressure Learning	Yaw rate sensor type reset	Air bleeding	Customization	Customization Reset	Theft alarm	Service remainder reset	Head lamp Auto leveling Diag mode	SAS Calibration	Keyless ID Registration	Keyless Reception Check	Key Registration	Additional Key Reg. (using key)	Steering lock unit Reg	Engine Key Code Reg.	Engine Key Code Registration, VIN Writing	Zero Calibration & System Test	HS initial position Clear	HS initial position Learning	Forced power supply output	Forced power supply output (stop)	TPMS ID Registration	TPMS ID Check
International	eK	ELC-AT / CVT / TC-SST	V	V	V	V	V																																		
International	eK	4WS / Electric Power Steering	V	V	V	V																																			
International	eK	ABS/ASC/ASTC/WSS	V	V	V	V										V	V																								
International	eK	SRS Airbag	V	V	V																																				
International	eK	Air Conditioner	V	V	V	V																																			
International	eK	ETACS(Electronic Time and Alarm Control System)	V	V	V	V	V							V							V	V					V	V													
International	eK	Meter	V	V	V	V																		V																	
International	eK	Steering Angle Sensor	V			V																				V															
International	eK	Electric Slide Door L	V	V	V	V																																			
International	eK	Electric Slide Door R	V	V	V	V																																			
International	eK	AFS / ACL / Leveling	V	V	V	V																													V	V					
International	i-MiEV	SYSTEM SEARCH																																							
International	i-MiEV	IMMOBILIZER	V	V		V																							V		V		V								
International	i-MiEV	4WS / Electric Power Steering	V	V	V	V																																			
International	i-MiEV	ABS/ASC/ASTC/WSS	V	V	V	V										V	V																								
International	i-MiEV	SRS Airbag	V	V	V																																				
International	i-MiEV	Air Conditioner	V	V	V	V																																			
International	i-MiEV	ETACS(Electronic Time and Alarm Control System)	V	V	V	V	V							V							V	V					V	V													
International	i-MiEV	Meter	V	V	V	V																		V																	
International	i-MiEV	Steering Angle Sensor				V																				V															
International	i-MiEV	EV-ECU	V	V	V	V																																			
International	i-MiEV	MiEV Remote System	V	V	V	V																																			
International	i-MiEV	BMU (Battery Monitoring Unit)	V	V	V	V																																			
International	i-MiEV	COMP / HTR	V	V	V	V																																			
International	i-MiEV	MCU (Motor Control Unit)	V	V	V	V																																			
International	i-MiEV	CMU1 (Cell Monitor Unit)		V		V																																			
International	i-MiEV	CMU2		V		V																																			
International	i-MiEV	CMU3		V		V																																			
International	i-MiEV	CMU4		V		V																																			
International	i-MiEV	CMU5		V		V																																			
International	i-MiEV	CMU6		V		V																																			
International	i-MiEV	CMU7		V		V																																			
International	i-MiEV	CMU8		V		V																																			
International	i-MiEV	CMU9		V		V																																			
International	i-MiEV	CMU10		V		V																																			
International	i-MiEV	CMU11		V		V																																			
International	i-MiEV	CMU12		V		V																																			

Nation	Vehicle	System		DTC Analysis	Data Analysis	Actuation Test	Identification	Special Function
Malaysia	SUTERA	ENGINE		V	V	V		
Malaysia	SUTERA	SRS-AIRBAG		V	V			
Malaysia	SURIA	SURIA	Select Kia PICANTO(SA) for diagnosis of this model					
Malaysia	CITRA	CITRA	Select Kia CARENS for diagnosis of this model					
Malaysia	RIA	RIA	Select Kia CARNIVAL/SEDONA(GO) for diagnosis of this model					
Malaysia	SORENTO	SORENTO	Select Kia SORENTO(BL) for diagnosis of this model					
Malaysia	BESTARI (Peugeot 206)	Engine	K6D SAGEM S2000	V	V	V	V	Initial Autoadaptive
Malaysia	BESTARI (Peugeot 207)	Engine	N6A BOSCH ME7.4.4	V	V	V	V	Initial Autoadaptive
Malaysia	BESTARI (Peugeot 208)	Engine	NFU BOSCH ME7.4.4	V	V	V	V	Initial Autoadaptive
Malaysia	BESTARI (Peugeot 209)	Engine	NFU BOSCH ME7.4.5	V	V	V	V	Initial Autoadaptive
Malaysia	BESTARI (Peugeot 210)	Engine	KFW J34P(Valeo)	V	V	V	V	Initial Autoadaptive
Malaysia	BESTARI (Peugeot 211)	Automatic Transaxle	BVA_AL4	V	V	V	V	AT Initialising the autoadaptive
Malaysia	BESTARI (Peugeot 212)	Driver information / Communication	Radio	V	V	V	V	VIN Code Radio Configuration
Malaysia	BESTARI (Peugeot 213)		Instrument panel	V	V	V	V	Instrument panel Configuration
Malaysia	BESTARI (Peugeot 214)		Switching module steering wheel	V	V	-	V	-
Malaysia	BESTARI (Peugeot 215)	Visibility/Lighting	Rain/sunlight sensor	V	-	-	V	-
Malaysia	BESTARI (Peugeot 216)	Airbag	Airbag SAC Central	V	V	-	V	Airbag Configuration Airbag Lock Airbag Unlock
Malaysia	BESTARI (Peugeot 217)	Active Safety	ABS TEVES MK20	V	V	V	V	Draining Simulation
Malaysia	BESTARI (Peugeot 218)	Active Safety	ABS TEVES MK70	V	V	V	V	Bleeding
Malaysia	BESTARI (Peugeot 219)	Active Safety	ESP TEVES MK60	V	V	V	V	Bleeding
Malaysia	BESTARI (Peugeot 220)	Built-In system interface	BSI	V	V	V	V	ECUs Present Customer Option Maintenance VIN code Programming by default Customer mode Engine immobiliser code and key Resetting to zero

Vehicle	ENG	System 1	Connector	System 2	DTC	Freeze frame	CURRENT DATA	ACTUATION TEST	ECU INFORMATION	VIN Registration	EVAP system close	ECT Learning Value Clear	A/F Ratio Learning Value Clear	TARGET IGN TIN ADJ	TARGET IDLE RPM ADJ	Target Ignition Timing Adjustment	Idle Air Volume Learning(Quick TAS)	Fuel Pressure Release	Target Idle RPM Adjustment	TP Swich/TP Sensor Idle Position Adjust	Check Fuel Lines	V/T Control Learn	Ethanol M/R Adjust	EXH V/T Control Learn	TP Position Learn Clear	A/F Sensor Learn Clear	Service Generation	DIF EX PRE Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Enter Injector Calibration Data	PTO Registration	DPF Data Clear	OFF Accelerator Position Signal	Idle Air Volume Learning	Closed Throttle Position Learning	G Sensor Calibration	A/F INITIAL LEARNING	STRT OPRTN CNTR CLEAR	CML B/DCHRG CRNT CLEAR
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT	V		V	V	V																												V			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)	V		V	V	V	V																														
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)	V				V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)	V		V	V	V																												V			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room	V		V	V	V																															V
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier	V		V																																	
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer	V		V	V																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt	V				V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS	V				V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front	V				V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-Sus	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rear View Camera			V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera			V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist	V		V																																	
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB	V		V	V	V																												V			

Vehicle	ENG	System 1	Connector	System 2	DTC	Freeze frame	CURRENT DATA	ACTUATION TEST	ECU INFORMATION	VIN Registration	EVAP system close	ECT Learning Value Clear	A/F Ratio Learning Value Clear	TARGET IGN TIN ADJ	TARGET IDLE RPM ADJ	Target Ignition Timing Adjustment	Idle Air Volume Learning(Quick TAS)	Fuel Pressure Release	Target Idle RPM Adjustment	TP Swich/TP Sensor Idle Position Adjust	Check Fuel Lines	V/T Control Learn	Ethanol M/R Adjust	EXH V/T Control Learn	TP Position Learn Clear	A/F Sensor Learn Clear	Service Generation	DIF EX PRE Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Enter Injector Calibration Data	PTO Registration	DPF Data Clear	OFF Accelerator Position Signal	Idle Air Volume Learning	Closed Throttle Position Learning	G Sensor Calibration	A/F INITIAL LEARNING	STRT OPRTN CNTR CLEAR	CML B/DCHRG CRNT CLEAR
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Engine	V		V	V	V																															
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	AT	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	CVT	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	ABS(Antilocked Braking System)	V		V		V																															
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Airbag	V				V																															
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)	V				V																															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EV/HEV	V	V	V	V	V	V																														
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Control	V		V		V																															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HV Battery	V		V	V	V																															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Charger	V		V	V	V																															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Brake	V		V	V	V																															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Shift	V		V		V																															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Telematics	V		V		V	V																														
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V										V	V	V	V	V	V	V
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT	V		V		V																												V			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)	V		V	V	V																															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)	V		V	V	V	V																														
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)	V		V		V																															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag	V		V		V																															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)	V		V	V	V																															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3	V		V		V																															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)	V																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)	V		V	V	V																											V			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room	V		V	V	V																															V
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key	V		V	V	V																															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position	V		V	V	V																															

Vehicle	ENG	System 1	Connector	System 2	DTC	Freeze frame	CURRENT DATA	ACTUATION TEST	ECU INFORMATION	VIN Registration	EVAP system close	ECT Learning Value Clear	A/F Ratio Learning Value Clear	TARGET IGN TIN ADJ	TARGET IDLE RPM ADJ	Target Ignition Timing Adjustment	Idle Air Volume Learning(Quick TAS)	Fuel Pressure Release	Target Idle RPM Adjustment	TP Swich/TP Sensor Idle Position Adjust	Check Fuel Lines	V/T Control Learn	Ethanol M/R Adjust	EXH V/T Control Learn	TP Position Learn Clear	A/F Sensor Learn Clear	Service Generation	DIF EX PRE Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Enter Injector Calibration Data	PTO Registration	DPF Data Clear	OFF Accelerator Position Signal	Idle Air Volume Learning	Closed Throttle Position Learning	G Sensor Calibration	A/F INITIAL LEARNING	STRT OPRTN CNTR CLEAR	CML B/DCHRG CRNT CLEAR
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier	V		V																																		
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer	V		V	V																																	
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt	V				V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS	V				V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front	V				V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-SUS	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rearview Camera			V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera			V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist	V		V																																		
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB	V		V	V	V																												V				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering)	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering)	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM	V		V		V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT	V		V	V	V																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM	V		V		V																																

Vehicle	ENG	System 1	Connector	System 2	Self-Learning Control	VVEL Position Sensor Adjustment Prep	Cumulative Sub-Battery Dischg Current Clear	Sub-Starter and Generator OPER Count Clear	SC Magnetic Clutch Engage Count Clear	Valve Timing Offset Data Clear	Wastegate Actuator Position Learn Value Clear	Enter Injector Calibration Data	EGR/V Learn Clear	PUMP LEANT CLEAR	DF EXH PRES SEN LEARN CLR	E/R AIR TEMP SEN LEARN CLR	FUEL INJ QUANTITY LEARNING	CONFIG CLR	INJ ADJ VAL CLR	EGR/V LEARN CLR	EXH PRSR SEN LEARN CLEAR	OC DATA CLEAR	PROGRAMMED VALUES	EGR ADAPTIVES	RESET PUMP FORCEFEEDING	RESET INJCTR ADAPTATIVE	TP POS LEARN CLR	EXH FUEL INJ DATA CLEAR	ZFC VALUE RESET	PRGRM REINITIALIZE	PRES REG ADAPTIVE LEARNING	P062F EXCLUSIVE FUNCTION	ZFC VALVE RESET	OC DATA LEAR	ENTER INJECTOR CODES	After DPF Regeneration	After DPF Replacement	EGR Valve Programming	Air Damper Valve Programming
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag								V	V																										
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-Sus																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rear View Camera																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																			

Vehicle	ENG	System 1	Connector	System 2	Self-Learning Control	VVEL Position Sensor Adjustment Prep	Cumulative Sub-Battery Dischg Current Clear	Sub-Starter and Generator OPER Count Clear	SC Magnetic Clutch Engage Count Clear	Valve Timing Offset Data Clear	Wastegate Actuator Position Learn Value Clear	Enter Injector Calibration Data	EGR/V Learn Clear	PUMP LEANT CLEAR	DF EXH PRES SEN LEARN CLR	E/R AIR TEMP SEN LEARN CLR	FUEL INJ QUANTITY LEARNING	CONFIG CLR	INJ ADJ VAL CLR	EGR/V LEARN CLR	EXH PRSR SEN LEARN CLEAR	OC DATA CLEAR	PROGRAMMED VALUES	EGR ADAPTIVES	RESET PUMP FORCEFEEDING	RESET INJCTR ADAPTATIVE	TP POS LEARN CLR	EXH FUEL INJ DATA CLEAR	ZFC VALUE RESET	PRGRM REINITIALIZE	PRES REG ADAPTIVE LEARNING	P062F EXCLUSIVE FUNCTION	ZFC VALVE RESET	OC DATA LEAR	ENTER INJECTOR CODES	After DPF Regeneration	After DPF Replacement	EGR Valve Programming	Air Damper Valve Programming
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																			
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	SYSTEM SEARCH																																			
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Engine																																			
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	AT																																			
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	CVT																																			
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	ABS(Antilocked Braking System)																																			
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Airbag																																			
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EV/HEV																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Control																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HV Battery																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Charger																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Brake																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Shift																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Telematics																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine	V	V	V	V	V	V	V																												
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag								V	V																										
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																			

Vehicle	ENG	System 1	Connector	System 2	Self-Learning Control	VVEL Position Sensor Adjustment Prep	Cumulative Sub-Battery Dischg Current Clear	Sub-Starter and Generator OPER Count Clear	SC Magnetic Clutch Engage Count Clear	Valve Timing Offset Data Clear	Wastegate Actuator Position Learn Value Clear	Enter Injector Calibration Data	EGR/V Learn Clear	PUMP LEANT CLEAR	DF EXH PRES SEN LEARN CLR	E/R AIR TEMP SEN LEARN CLR	FUEL INJ QUANTITY LEARNING	CONFIG CLR	INJ ADJ VAL CLR	EGR/V LEARN CLR	EXH PRSR SEN LEARN CLEAR	OC DATA CLEAR	PROGRAMMED VALUES	EGR ADAPTIVES	RESET PUMP FORCEFEEDING	RESET INJCTR ADAPTATIVE	TP POS LEARN CLR	EXH FUEL INJ DATA CLEAR	ZFC VALUE RESET	PRGRM REINITIALIZE	PRES REG ADAPTIVE LEARNING	P062F EXCLUSIVE FUNCTION	ZFC VALVE RESET	OC DATA LEAR	ENTER INJECTOR CODES	After DPF Regeneration	After DPF Replacement	EGR Valve Programming	Air Damper Valve Programming
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-SUS																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rearview Camera																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																			

Vehicle	ENG	System 1	Connector	System 2	CC/SL Programming	E/O CC/SL Programming	FLYWHL TGT Programming	PRPR Rich Sensor Programming	Exhaust Throttle Valve Programming	Swirl Flap Programming	Turbocharger Programming	Adaptives on ETC Actuator Malfunction	Air Flow Meter Programming	Manifold Pressure Sensor Programming	DIFF Exhaust Press. Sensor	Low Pressure EGR Valve Programming	Engine Adaptives	Swirl Flap	Rail Press Sensor Adaptives	Number Of Starting Cycles	Injection Pump Adaptatives	Fuel Sply Prec	H/P Fuel Pump Initial Starts Counter Reset	H/P Fuel Pump Total Starts Counter Reset	INJ ADJ VAL Regist	Speed Limiter	Commercial VHCL Idle Speed MOD	Service Regeneration	Fuel Supply Prevention	Number of Starting 1	Number of Starting 2	Number of Starting 3	Number of Starting 4	Flywheel Target Programming	Exhaust Air Flap Programming	Adaptives on Air Intake Flap Malfunction	Fuel Pump Programming	Injector Adaptives	Air Path Programming	EGR Programming
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-Sus																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rear View Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																				

Vehicle	ENG	System 1	Connector	System 2	CC/SL Programming	E/O CC/SL Programming	FLYWHL TGT Programming	PRPR Rich Sensor Programming	Exhaust Throttle Valve Programming	Swirl Flap Programming	Turbocharger Programming	Adaptives on ETC Actuator Malfunction	Air Flow Meter Programming	Manifold Pressure Sensor Programming	DIFF Exhaust Press. Sensor	Low Pressure EGR Valve Programming	Engine Adaptives	Swirl Flap	Rail Press Sensor Adaptives	Number Of Starting Cycles	Injection Pump Adaptatives	Fuel Sply Prec	H/P Fuel Pump Initial Starts Counter Reset	H/P Fuel Pump Total Starts Counter Reset	INJ ADJ VAL Regist	Speed Limiter	Commercial VHCL Idle Speed MOD	Service Regeneration	Fuel Supply Prevention	Number of Starting 1	Number of Starting 2	Number of Starting 3	Number of Starting 4	Flywheel Target Programming	Exhaust Air Flap Programming	Adaptives on Air Intake Flap Malfunction	Fuel Pump Programming	Injector Adaptives	Air Path Programming	EGR Programming
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Engine																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	AT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	CVT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Airbag																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EV/HEV																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HV Battery																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Charger																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Brake																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Shift																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Telematics																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																				

Vehicle	ENG	System 1	Connector	System 2	CC/SL Programming	E/O CC/SL Programming	FLYWHL TGT Programming	PRPR Rich Sensor Programming	Exhaust Throttle Valve Programming	Swirl Flap Programming	Turbocharger Programming	Adaptives on ETC Actuator Malfunction	Air Flow Meter Programming	Manifold Pressure Sensor Programming	DIFF Exhaust Press. Sensor	Low Pressure EGR Valve Programming	Engine Adaptives	Swirl Flap	Rail Press Sensor Adaptives	Number Of Starting Cycles	Injection Pump Adaptatives	Fuel Sply Prec	H/P Fuel Pump Initial Starts Counter Reset	H/P Fuel Pump Total Starts Counter Reset	INJ ADJ VAL Regist	Speed Limiter	Commercial VHCL Idle Speed MOD	Service Regeneration	Fuel Supply Prevention	Number of Starting 1	Number of Starting 2	Number of Starting 3	Number of Starting 4	Flywheel Target Programming	Exhaust Air Flap Programming	Adaptives on Air Intake Flap Malfunction	Fuel Pump Programming	Injector Adaptives	Air Path Programming	EGR Programming
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-SUS																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rearview Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				

Vehicle	ENG	System 1	Connector	System 2	Proportional Richness Sensor Programming	Fuel Rail Press Limiting Injection Counter Clear	Adaptives After Regenerating Particle Filter	A/F Sensor 1 Learn Clear	A/F Sensor 2 Learn Clear	TC Boost Control Actuator Position Learning	Read VIN	Decrement Idle Speed	Increment Idle Speed	Program Reinitialize	Lock Injector Control	Pressure Regulation Adaptives	Programmed Valves	EEPROM Clear Confirm	ENGINE BRAKE ADJ	CONFORM CVTF DETERIORATION	ECO MODE RESET FUNCTION	Initialization	G Sensor Calibration	Erase Calibration Data	Erase Learning Value	Erase Memory Data	Clutch Point Learning	Electric O.P. Air Bleeding	FWD Clutch Point Learning	MAX. Clutch STRK MSRMNT	Clutch Touchpoint Adjustment	TM Actuator Self Adjustment	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	Steering Angle Sensor Adjustment	Deceleration G Sensor Calibration	Valve Calibration	Stroke Sensor Calibration
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine	V	V	V	V	V	V	V	V	V	V	V	V	V																							
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT														V	V	V	V	V	V	V	V	V	V	V	V	V	V	V								
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																													V	V	V	V	V	V	V	V
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)																													V							
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																													V							
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																V				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-Sus																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rear View Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																				

Vehicle	ENG	System 1	Connector	System 2	Proportional Richness Sensor Programming	Fuel Rail Press Limiting Injection Counter Clear	Adaptives After Regenerating Particle Filter	A/F Sensor 1 Learn Clear	A/F Sensor 2 Learn Clear	TC Boost Control Actuator Position Learning	Read VIN	Decrement Idle Speed	Increment Idle Speed	Program Reinitialize	Lock Injector Control	Pressure Regulation Adaptives	Programmed Valves	EEPROM Clear Confirm	ENGINE BRAKE ADJ	CONFORM CVTF DETERIORATION	ECO MODE RESET FUNCTION	Initialization	G Sensor Calibration	Erase Calibration Data	Erase Learning Value	Erase Memory Data	Clutch Point Learning	Electric O.P. Air Bleeding	FWD Clutch Point Learning	MAX. Clutch STRK MSRMNT	Clutch Touchpoint Adjustment	TM Actuator Self Adjustment	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	Steering Angle Sensor Adjustment	Deceleration G Sensor Calibration	Valve Calibration	Stroke Sensor Calibration
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Engine																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	AT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	CVT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Airbag																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EV/HEV																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HV Battery																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Charger																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Brake																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Shift																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Telematics																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT													V	V	V	V	V	V	V	V	V	V	V	V	V	V	V								
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																												V	V	V	V				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																V	V	V	V
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)																												V								
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																				

Vehicle	ENG	System 1	Connector	System 2	Proportional Richness Sensor Programming	Fuel Rail Press Limiting Injection Counter Clear	Adaptives After Regenerating Particle Filter	A/F Sensor 1 Learn Clear	A/F Sensor 2 Learn Clear	TC Boost Control Actuator Position Learning	Read VIN	Decrement Idle Speed	Increment Idle Speed	Program Reinitialize	Lock Injector Control	Pressure Regulation Adaptives	Programmed Valves	EEPROM Clear Confirm	ENGINE BRAKE ADJ	CONFORM CVTF DETERIORATION	ECO MODE RESET FUNCTION	Initialization	G Sensor Calibration	Erase Calibration Data	Erase Learning Value	Erase Memory Data	Clutch Point Learning	Electric O.P. Air Bleeding	FWD Clutch Point Learning	MAX. Clutch STRK MSRMNT	Clutch Touchpoint Adjustment	TM Actuator Self Adjustment	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	Steering Angle Sensor Adjustment	Deceleration G Sensor Calibration	Valve Calibration	Stroke Sensor Calibration
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																												V								
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																V				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-SUS																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rearview Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				

Vehicle	ENG	System 1	Connector	System 2	Check Target Teeth	Bleed HYD Unit Brake Circle	Acceleation Sensor	Steering Wheel Angle Sensor	Write Date Of Last After Sales OPE	Speedo Index	Steering Wheel Angle Sensor	Write Date Of Last After Sales OPE	Speedo Index	Config Clear	Injector Adpatation Valve Clear	Pump Learn Clear	Lock Computer	Unlock Computer	Steering Angle Adjustment	Power Steering Fluid Air Bleeding	C/U Initialization (20 digts)	Program Mode	C/U Initialization	RESET SETTING VALUE	Steering Lock Release (Key ID Erase)	DOOR LOCK-UNLOCK SET	AUTOMATIC DOOR LOCK SELECT	AUTOMATIC DOOR UNLOCK SELECT	AUTOMATIC DOOR LOCK/UNLOCK SELECT	Signature Light Setting	R Lamp Timer Logic Set	Room Lamp On Time Set	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	Fog Lamp Override	AUTO LIGHT LOGIC SET	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	ILL DELAY SET
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)	V	V	V	V	V	V	V	V	V																											
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag										V	V	V	V	V																						
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3															V	V																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																	V	V	V																	
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)																				V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-Sus																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rear View Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																				

Vehicle	ENG	System 1	Connector	System 2	Check Target Teeth	Bleed HYD Unit Brake Circle	Acceleation Sensor	Steering Wheel Angle Sensor	Write Date Of Last After Sales OPE	Speedo Index	Steering Wheel Angle Sensor	Write Date Of Last After Sales OPE	Speedo Index	Config Clear	Injector Adpatation Valve Clear	Pump Learn Clear	Lock Computer	Unlock Computer	Steering Angle Adjustment	Power Steering Fluid Air Bleeding	C/U Initialization (20 digts)	Program Mode	C/U Initialization	RESET SETTING VALUE	Steering Lock Release (Key ID Erase)	DOOR LOCK-UNLOCK SET	AUTOMATIC DOOR LOCK SELECT	AUTOMATIC DOOR UNLOCK SELECT	AUTOMATIC DOOR LOCK/UNLOCK SELECT	Signature Light Setting	R Lamp Timer Logic Set	Room Lamp On Time Set	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	Fog Lamp Override	AUTO LIGHT LOGIC SET	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	ILL DELAY SET
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Engine																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	AT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	CVT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Airbag																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EV/HEV																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HV Battery																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Charger																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Brake																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Shift																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Telematics																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)	V	V	V	V	V	V																														
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)							V	V	V																											
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag										V	V	V	V	V																						
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3															V	V																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																	V	V	V																	
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)																				V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																				

Vehicle	ENG	System 1	Connector	System 2	Check Target Teeth	Bleed HYD Unit Brake Circle	Acceleation Sensor	Steering Wheel Angle Sensor	Write Date Of Last After Sales OPE	Speedo Index	Steering Wheel Angle Sensor	Write Date Of Last After Sales OPE	Speedo Index	Config Clear	Injector Adpatation Valve Clear	Pump Learn Clear	Lock Computer	Unlock Computer	Steering Angle Adjustment	Power Steering Fluid Air Bleeding	C/U Initialization (20 digts)	Program Mode	C/U Initialization	RESET SETTING VALUE	Steering Lock Release (Key ID Erase)	DOOR LOCK-UNLOCK SET	AUTOMATIC DOOR LOCK SELECT	AUTOMATIC DOOR UNLOCK SELECT	AUTOMATIC DOOR LOCK/UNLOCK SELECT	Signature Light Setting	R Lamp Timer Logic Set	Room Lamp On Time Set	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	Fog Lamp Override	AUTO LIGHT LOGIC SET	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	ILL DELAY SET
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-SUS																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rearview Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				

Vehicle	ENG	System 1	Connector	System 2	HEAD LIGHT TIMER	Drop Wiper Function Set	Rain Sensor Wiper Function Set	WIPER SPEED SETTING	HAZARD ANSWER BACK	Remote Climate Cont Answer Back Function	ROOM LAMP BAT SAV SET	ROOM LAMP TIMER SET	IGN Battery Saver Set	ACC Battery Saver Set	PW DOWN SET	LOCK/UNLOCK BY I-KEY	TRUNK/GLASS HATCH OPEN	Anti Key Lock In Function	Answer Back I-Key Unlock	Intelligent Key Link Set	Answer Back I-Key Lock	HORN WITH KEYLESS LOCK	ENGINE START BY I-KEY	INSIDE ANT DIAGNOSIS	WELCOME LIGHT OP SET	CONFIRM KEY FOB ID	Retractable Mirror Set	SHORT CRANKING OUTPUT	WELCOME LIGHT SELECT	PANIC ALARM SET	LO-BATT OF KEY FOB WARN	AUTO LOCK SET	ANSWER BACK FUNCTION	TRUNK OPEN DELAY	THEFT ALM TRG	SECURITY ALARM SET(SIREN)	SECURITY ALARM SET	SIREN SET	CONFIRM DONGLE ID	ID READ
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key					V							V	V					V	V							V			V							
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-Sus																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rear View Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																				

Vehicle	ENG	System 1	Connector	System 2	HEAD LIGHT TIMER	Drop Wiper Function Set	Rain Sensor Wiper Function Set	WIPER SPEED SETTING	HAZARD ANSWER BACK	Remote Climate Cont Answer Back Function	ROOM LAMP BAT SAV SET	ROOM LAMP TIMER SET	IGN Battery Saver Set	ACC Battery Saver Set	PW DOWN SET	LOCK/UNLOCK BY I-KEY	TRUNK/GLASS HATCH OPEN	Anti Key Lock In Function	Answer Back I-Key Unlock	Intelligent Key Link Set	Answer Back I-Key Lock	HORN WITH KEYLESS LOCK	ENGINE START BY I-KEY	INSIDE ANT DIAGNOSIS	WELCOME LIGHT OP SET	CONFIRM KEY FOB ID	Retractable Mirror Set	SHORT CRANKING OUTPUT	WELCOME LIGHT SELECT	PANIC ALARM SET	LO-BATT OF KEY FOB WARN	AUTO LOCK SET	ANSWER BACK FUNCTION	TRUNK OPEN DELAY	THEFT ALM TRG	SECURITY ALARM SET(SIREN)	SECURITY ALARM SET	SIREN SET	CONFIRM DONGLE ID	ID READ
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Engine																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	AT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	CVT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Airbag																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EV/HEV																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HV Battery																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Charger																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Brake																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Shift																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Telematics																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key					V							V	V					V	V							V			V							
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																				

Vehicle	ENG	System 1	Connector	System 2	HEAD LIGHT TIMER	Drop Wiper Function Set	Rain Sensor Wiper Function Set	WIPER SPEED SETTING	HAZARD ANSWER BACK	Remote Climate Cont Answer Back Function	ROOM LAMP BAT SAV SET	ROOM LAMP TIMER SET	IGN Battery Saver Set	ACC Battery Saver Set	PW DOWN SET	LOCK/UNLOCK BY I-KEY	TRUNK/GLASS HATCH OPEN	Anti Key Lock In Function	Answer Back I-Key Unlock	Intelligent Key Link Set	Answer Back I-Key Lock	HORN WITH KEYLESS LOCK	ENGINE START BY I-KEY	INSIDE ANT DIAGNOSIS	WELCOME LIGHT OP SET	CONFIRM KEY FOB ID	Retractable Mirror Set	SHORT CRANKING OUTPUT	WELCOME LIGHT SELECT	PANIC ALARM SET	LO-BATT OF KEY FOB WARN	AUTO LOCK SET	ANSWER BACK FUNCTION	TRUNK OPEN DELAY	THEFT ALM TRG	SECURITY ALARM SET(SIREN)	SECURITY ALARM SET	SIREN SET	CONFIRM DONGLE ID	ID READ
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-SUS																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rearview Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				

Vehicle	ENG	System 1	Connector	System 2	ID REGIST	Switching The Status of TPMS Beteen On and Off	Switch TPMS Between On/Off	SECURITY DOOR LOCK SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK	RR WIP RVRS SET	HAZARD LAMP SET	D/LOCK VHCL SPD AJT	HORN CHIRP SET	DROP WIPE FUNC SET	RAIN SEN WIP FUNC SET	TAKE OUT FROM WINDDOW WARN	KEYLESS FUNCTION	TRUNK OPEN SET	ANTI-LOCK OUT SET	REMO CONT ID ERASUR	REMO CONT ID REGIST	REMO CONT ID CONFIR	MULTI ANSWER BACK SET	RETAINED PWR SET	ANTI KEY LOCK IN FUNCTI	SECURITY ALARM SET	THEFT ALM TRG	HZRD REM SET	CUSTOM A/LIGHT SETTING	Auto ACC Function (Audio/Navi Set After IGN Off)	Auto Unlock Type	Auto Lock Function	Auto Unlock Function	Set R-DEF Timer	Answerback Keyless Lock Unlock	Twilight ON	Wiper Link
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key															V	V	V	V																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor	V	V																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-Sus																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rear View Camera																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																					
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																					

Vehicle	ENG	System 1	Connector	System 2	ID REGIST	Switching The Status of TPMS Beteen On and Off	Switch TPMS Between On/Off	SECURITY DOOR LOCK SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK	RR WIP RVRS SET	HAZARD LAMP SET	D/LOCK VHCL SPD AJT	HORN CHIRP SET	DROP WIPE FUNC SET	RAIN SEN WIP FUNC SET	TAKE OUT FROM WINDDOW WARN	KEYLESS FUNCTION	TRUNK OPEN SET	ANTI-LOCK OUT SET	REMO CONT ID ERASUR	REMO CONT ID REGIST	REMO CONT ID CONFIR	MULTI ANSWER BACK SET	RETAINED PWR SET	ANTI KEY LOCK IN FUNCTI	SECURITY ALARM SET	THEFT ALM TRG	HZRD REM SET	CUSTOM A/LIGHT SETTING	Auto ACC Function (Audio/Navi Set After IGN Off)	Auto Unlock Type	Auto Lock Function	Auto Unlock Function	Set R-DEF Timer	Answerback Keyless Lock Unlock	Twilight ON	Wiper Link
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Engine																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	AT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	CVT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Airbag																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EV/HEV																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HV Battery																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Charger																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Brake																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Shift																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Telematics																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)	V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key															V	V	V	V																		
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																				

Vehicle	ENG	System 1	Connector	System 2	ID REGIST	Switching The Status of TPMS Beteen On and Off	Switch TPMS Between On/Off	SECURITY DOOR LOCK SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK	RR WIP RVRS SET	HAZARD LAMP SET	D/LOCK VHCL SPD AJT	HORN CHIRP SET	DROP WIPE FUNC SET	RAIN SEN WIP FUNC SET	TAKE OUT FROM WINDDOW WARN	KEYLESS FUNCTION	TRUNK OPEN SET	ANTI-LOCK OUT SET	REMO CONT ID ERASUR	REMO CONT ID REGIST	REMO CONT ID CONFIR	MULTI ANSWER BACK SET	RETAINED PWR SET	ANTI KEY LOCK IN FUNCTI	SECURITY ALARM SET	THEFT ALM TRG	HZRD REM SET	CUSTOM A/LIGHT SETTING	Auto ACC Function (Audio/Navi Set After IGN Off)	Auto Unlock Type	Auto Lock Function	Auto Unlock Function	Set R-DEF Timer	Answerback Keyless Lock Unlock	Twilight ON	Wiper Link
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor	V	V																																		
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-SUS																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rearview Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				

Vehicle	ENG	System 1	Connector	System 2	Daytime Running Light Setting	Rain Sensor	FR RR Drip	Rear Wiper Link With Reverse Setting	3-Time Flasher Setting	IGN/ACC Battery Saver	Answer Back I-Key Lock Unlock	Answerback I-Key Lock Unlock	LEVELIZER ADJUSTMEN	ANSWER BACK WITH I-KEY UNLOCK	CONFIRM KEY FOR ID	LOW BATT OF KEY FOR WARN	I-KEY FUNCTION	SELECTIVE UNLOCK FUNCTION	ANSWER BACK WITH I-KEY LOCK	AUTO RELOCK TIMER	P/W DOWN DELAY	LUG ROOM ENGINE START	Intelligent Key Register	EXIT SEAT SLIDE SETTING	EXIT TILT SETTING	SEAT SLIDE VOLUME SET	Outside Air Temperature Diagnosis	Fuel meter diagnosis(analog pointer)	Warning lamp diagnosis	SENSOR INITIALISE	TEMP Set Correct	REC Memory Set	FRE Memory Set	Blow Set	Gas Sensor Adjustment	Clean SW Set	Door Motor Starting Position Reset	Target Evaporator Temp Upper Limit Setting	Stop/Start System Operation Cond Setting	Air Inlet Change Setting
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)	V	V	V	V	V	V	V	V																												
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key											V	V	V	V	V	V	V	V	V																	
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																				V	V	V														
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																							V	V	V											
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																										V										
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																											V	V	V	V	V	V	V	V	V	V
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-Sus																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rear View Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																				

Vehicle	ENG	System 1	Connector	System 2	Daytime Running Light Setting	Rain Sensor	FR RR Drip	Rear Wiper Link With Reverse Setting	3-Time Flasher Setting	IGN/ACC Battery Saver	Answer Back I-Key Lock Unlock	Answerback I-Key Lock Unlock	LEVELIZER ADJUSTMEN	ANSWER BACK WITH I-KEY UNLOCK	CONFIRM KEY FOR ID	LOW BATT OF KEY FOR WARN	I-KEY FUNCTION	SELECTIVE UNLOCK FUNCTION	ANSWER BACK WITH I-KEY LOCK	AUTO RELOCK TIMER	P/W DOWN DELAY	LUG ROOM ENGINE START	Intelligent Key Register	EXIT SEAT SLIDE SETTING	EXIT TILT SETTING	SEAT SLIDE VOLUME SET	Outside Air Temperature Diagnosis	Fuel meter diagnosis(analog pointer)	Warning lamp diagnosis	SENSOR INITIALISE	TEMP Set Correct	REC Memory Set	FRE Memory Set	Blow Set	Gas Sensor Adjustment	Clean SW Set	Door Motor Starting Position Reset	Target Evaporator Temp Upper Limit Setting	Stop/Start System Operation Cond Setting	Air Inlet Change Setting
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Engine																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	AT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	CVT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Airbag																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EV/HEV																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HV Battery																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Charger																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Brake																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Shift																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Telematics																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)	V	V	V	V	V	V	V	V																												
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key											V	V	V	V	V	V	V	V	V																	
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																				V	V	V														

Vehicle	ENG	System 1	Connector	System 2	Daytime Running Light Setting	Rain Sensor	FR RR Drip	Rear Wiper Link With Reverse Setting	3-Time Flasher Setting	IGN/ACC Battery Saver	Answer Back I-Key Lock Unlock	Answerback I-Key Lock Unlock	LEVELIZER ADJUSTMEN	ANSWER BACK WITH I-KEY UNLOCK	CONFIRM KEY FOR ID	LOW BATT OF KEY FOR WARN	I-KEY FUNCTION	SELECTIVE UNLOCK FUNCTION	ANSWER BACK WITH I-KEY LOCK	AUTO RELOCK TIMER	P/W DOWN DELAY	LUG ROOM ENGINE START	Intelligent Key Register	EXIT SEAT SLIDE SETTING	EXIT TILT SETTING	SEAT SLIDE VOLUME SET	Outside Air Temperature Diagnosis	Fuel meter diagnosis(analog pointer)	Warning lamp diagnosis	SENSOR INITIALISE	TEMP Set Correct	REC Memory Set	FRE Memory Set	Blow Set	Gas Sensor Adjustment	Clean SW Set	Door Motor Starting Position Reset	Target Evaporator Temp Upper Limit Setting	Stop/Start System Operation Cond Setting	Air Inlet Change Setting
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																							V	V	V											
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																										V										
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																											V	V	V	V	V	V	V	V	V	V
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-SUS																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rearview Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				

Vehicle	ENG	System 1	Connector	System 2	Air Flow Reduction Setting	Aroma Setting	Fragrance Setting	Blower Motor Setting	Aroma Diffuser Setting	Rear Temp Set Correct	Target Max RPM Adjust At Pre-Climate	Target Max RPM Adjust At Idle	*COMP Operation At DEF(PRI_A/C)(TBD)	FEB default setting	Steering Angle Sensor Adjustment	FRONT RIGHT ACTUATOR	FRONT LEFT ACTUATOR	REAR RIGHT ACTUATOR	REAR LEFT ACTUATOR	FOUR WHEEL ACTUATOR	Auto AIM	AIM Check	STANDARD HEIGHT LEVEL	ADJUST HEIGHT INI	CLEAR HEIGHT INI	Corner Sensor Distance Set	Center Sensor Distance Set	Volume Setting	Trailer Hitch Mode	CALIBRATE ALL	Trailer Hitch Detection Range Adjustment	FEB Default Setting	Cause of Auto-Cancel	Actuator 0 Point Learning	Start Brake Pad Replacement	Finish Brake Pad Replacement	Initialization Position Dajustment	Clutch Sensor Reset	Brake Operation	Brake Relese
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)	V	V	V	V	V	V	V	V	V																										
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)										V																									
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV											V																								
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-Sus												V	V	V	V	V																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rear View Camera																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																	V	V																	
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																			V	V	V														
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																						V	V	V	V		V								
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																										V									
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																											V	V							
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																			
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																													V	V	V	V	V	V	V

Vehicle	ENG	System 1	Connector	System 2	Air Flow Reduction Setting	Aroma Setting	Fragrance Setting	Blower Motor Setting	Aroma Diffuser Setting	Rear Temp Set Correct	Target Max RPM Adjust At Pre-Climate	Target Max RPM Adjust At Idle	*COMP Operation At DEF(PRI_A/C)(TBD)	FEB default setting	Steering Angle Sensor Adjustment	FRONT RIGHT ACTUATOR	FRONT LEFT ACTUATOR	REAR RIGHT ACTUATOR	REAR LEFT ACTUATOR	FOUR WHEEL ACTUATOR	Auto AIM	AIM Check	STANDARD HEIGHT LEVEL	ADJUST HEIGHT INI	CLEAR HEIGHT INI	Corner Sensor Distance Set	Center Sensor Distance Set	Volume Setting	Trailer Hitch Mode	CALIBRATE ALL	Trailer Hitch Detection Range Adjustment	FEB Default Setting	Cause of Auto-Cancel	Actuator 0 Point Learning	Start Brake Pad Replacement	Finish Brake Pad Replacement	Initialization Position Dajustment	Clutch Sensor Reset	Brake Operation	Brake Relese
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																				
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	SYSTEM SEARCH																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Engine																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	AT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	CVT																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Airbag																																				
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EV/HEV																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Control																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HV Battery																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Charger																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Brake																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Shift																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Telematics																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key																																				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																				

Vehicle	ENG	System 1	Connector	System 2	Air Flow Reduction Setting	Aroma Setting	Fragrance Setting	Blower Motor Setting	Aroma Diffuser Setting	Rear Temp Set Correct	Target Max RPM Adjust At Pre-Climate	Target Max RPM Adjust At Idle	*COMP Operation At DEF(PRI_A/C)(TBD)	FEB default setting	Steering Angle Sensor Adjustment	FRONT RIGHT ACTUATOR	FRONT LEFT ACTUATOR	REAR RIGHT ACTUATOR	REAR LEFT ACTUATOR	FOUR WHEEL ACTUATOR	Auto AIM	AIM Check	STANDARD HEIGHT LEVEL	ADJUST HEIGHT INI	CLEAR HEIGHT INI	Corner Sensor Distance Set	Center Sensor Distance Set	Volume Setting	Trailer Hitch Mode	CALIBRATE ALL	Trailer Hitch Detection Range Adjustment	FEB Default Setting	Cause of Auto-Cancel	Actuator 0 Point Learning	Start Brake Pad Replacement	Finish Brake Pad Replacement	Initialization Position Dajustment	Clutch Sensor Reset	Brake Operation	Brake Relese
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)	V	V	V	V	V	V	V	V	V																										
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)										V																									
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV											V																								
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-SUS												V	V	V	V	V																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rearview Camera																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																	V	V																	
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																			V	V	V														
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																						V	V	V	V		V								
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																										V									
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																											V	V							
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB																													V	V	V	V	V	V	V
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering)																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																																			

Vehicle	ENG	System 1	Connector	System 2	System Mode Change	Auto Activation On (AT/CVT)	Non-Viewable Area Reminder	Select Language of Warning Message	Predictive Course Line Display	Initalize Camera Image Calibration	Steering Angle Sensor Adjustment	Parts With Door Mirror Auto Fold Function	Sonar Off Pop-Up Display Setting Change	Cause Of LDW Cancel	Cause Of BSW Cancel	Cause OF IPA Cancel	Cause Of PSR Cancel	Calibrating Camera Image (Front Camera)	Calibrating Camera Image (Pass-Side Camera)	Calibrating Camera Image (DR-Side Camera)	Calibrating Camera Image (Rear Camera)	ANC SETTING	ASC SETTING	CK Fuel Press and INTRNL LKTGHTNSS of FL System	Actuation of Fuel Pump	Battery Gradual Cap Loss Data Clear	HV Batt J/B Data Clear	Specific DTC Clear	Resolver Write	Clear Output Limit Reason	Resolver Offset	Charge current limitation history	Stroke Sensor 0 Point Learning	Actuator 0 Point Learning	P Position Learning Value Clear	TCU Activate Setting
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-Sus																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rear View Camera																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB	V	V																														

Vehicle	ENG	System 1	Connector	System 2	System Mode Change	Auto Activation On (AT/CVT)	Non-Viewable Area Reminder	Select Language of Warning Message	Predictive Course Line Display	Initalize Camera Image Calibration	Steering Angle Sensor Adjustment	Parts With Door Mirror Auto Fold Function	Sonar Off Pop-Up Display Setting Change	Cause Of LDW Cancel	Cause Of BSW Cancel	Cause OF IPA Cancel	Cause Of PSR Cancel	Calibrating Camera Image (Front Camera)	Calibrating Camera Image (Pass-Side Camera)	Calibrating Camera Image (DR-Side Camera)	Calibrating Camera Image (Rear Camera)	ANC SETTING	ASC SETTING	CK Fuel Press and INTRNL LKTGHTNSS of FL System	Actuation of Fuel Pump	Battery Gradual Cap Loss Data Clear	HV Batt J/B Data Clear	Specific DTC Clear	Resolver Write	Clear Output Limit Reason	Resolver Offset	Charge current limitation history	Stroke Sensor 0 Point Learning	Actuator 0 Point Learning	P Position Learning Value Clear	TCU Activate Setting
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)			V	V	V	V	V	V	V	V	V	V	V	V	V	V	V															
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																		V	V													
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering 1)																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering 2)																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																
Passenger Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																				V	V											
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	SYSTEM SEARCH																																
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Engine																																
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	AT																																
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	CVT																																
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	ABS(Antilocked Braking System)																																
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	Airbag																																
Passenger Car	ALL MODEL	ALL TYPE	14PIN CONNECTOR	All Mode 4WD(4 Wheel Drive)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	SYSTEM SEARCH																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EV/HEV																						V	V	V								
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Control																									V	V	V					
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HV Battery																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Charger																												V				
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Brake																													V			
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Shift																															V	
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Telematics																																V
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Engine																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AT/CVT																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilock Braking System)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ABS(Antilocked Braking System)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Airbag																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WD(e-4WD/All Mode AWD)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EPS(Electric Power Steering)/DAST3																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	NATS(NISSAN Anti-Theft System)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BCM(Body Control Module)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	IPDM Engine Room																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Intelligent Key																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Drive Position																																

Vehicle	ENG	System 1	Connector	System 2	System Mode Change	Auto Activation On (AT/CVT)	Non-Viewable Area Reminder	Select Language of Warning Message	Predictive Course Line Display	Initalize Camera Image Calibration	Steering Angle Sensor Adjustment	Parts With Door Mirror Auto Fold Function	Sonar Off Pop-Up Display Setting Change	Cause Of LDW Cancel	Cause Of BSW Cancel	Cause OF IPA Cancel	Cause Of PSR Cancel	Calibrating Camera Image (Front Camera)	Calibrating Camera Image (Pass-Side Camera)	Calibrating Camera Image (DR-Side Camera)	Calibrating Camera Image (Rear Camera)	ANC SETTING	ASC SETTING	CK Fuel Press and INTRNL LKTGHTNSS of FL System	Actuation of Fuel Pump	Battery Gradual Cap Loss Data Clear	HV Batt J/B Data Clear	Specific DTC Clear	Resolver Write	Clear Output Limit Reason	Resolver Offset	Charge current limitation history	Stroke Sensor 0 Point Learning	Actuator 0 Point Learning	P Position Learning Value Clear	TCU Activate Setting
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Meter/Air Conditioner Amplifier																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Head Lamp Levelizer																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Slide Door Right																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Precrash Seatbelt																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	RAS/HICAS																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	4WAS(4 Wheel Active Steering) Front																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	HVAC(Heating/Ventilating and Air-Conditioning)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ICC(Intelligent Cruise Control)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Pop Up Hood																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Pressure Monitor																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi AV																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	E-SUS																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Auto Back Door																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Rearview Camera																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	S/Blind Camera																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Lane Camera																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Air Levelizer																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Diff Lock																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Sonar																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Motor Assist																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	CAN Gateway																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Chassis Control																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Laser/Radar																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Multi Display																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EHS/PKB	V	V																														
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	AVM(Around View Monitor)			V	V	V	V	V	V	V	V	V	V	V	V	V	V	V															
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	VSP(Vehicle Sound for Pedestrians)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	PTC Heater																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	ANC(Active Noise Control)																		V	V													
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 1(Directive Adaptive Steering)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	DAST 2(Directive Adaptive Steering)																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Left																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Side Radar Right																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	EMCM																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	BSW/Buzzer																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	Accle Pedal ACT																																
Electric/Hybrid Car	ALL MODEL	ALL TYPE	16PIN CONNECTOR	FSCM																				V	V											

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	Program CAN configuration	Injector Cutoff Test	Adjust idle speed	Adjust idle drive	Idle air control	RPM control	Injector Cutoff	Reset TC signal status	Reset learned values	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Reset TC signal status	Calibration	Steering angle sensor calibration	Program transponder key	Erase transponder key	Reset Immobilizer	Program Immobilizer output	Reset service interval	Erase remote keys	Program remote key	Reset body control module	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Reset IAC block learn map	Reset ECU	Fuel pump relay test	Program tyre circumference	Bleed clutch hydraulic	Learn gearbox parameters	Touch point adaptation	Additional Touch Point Adaption	Clutch control test	Read security PIN code	BCM link to ECM/Immobilizer	Idle Test	Fuel Correction Test	Service Regeneration
Astra-F	Engine	14 SE	V			V																																													
Astra-F	Engine	16 LZ 2	V			V																																													
Astra-F	Engine	16 NZR	V			V																																													
Astra-F	Engine	18 SE	V			V																																													
Astra-F	Engine	C 14 NZ	V			V																																													
Astra-F	Engine	C 14 SE	V			V																																													
Astra-F	Engine	C 16 SE	V			V																																													
Astra-F	Engine	C 18 SEL	V	V	V	V			V	V	V	V	V																																						
Astra-F	Engine	X 14 NZ	V			V																																													
Astra-F	Engine	X 14 XE	V			V																																													
Astra-F	Engine	X 16 NE	V			V																																													
Astra-F	Engine	X 16 SZR	V	V	V	V																																													
Astra-F	Engine	X 16 XEL	V			V																																													
Astra-F	Engine	X 18 XE	V			V																																													
Astra-F	Engine	X 20 XEV	V	V	V	V																																													
Astra-F	Transmission	AF 13/14/20	V	V	V	V																																													
Astra-F	Transmission	AF 13II/20/22/30	V	V	V	V								V	V																																				
Astra-F	Body	Immobiliser	V	V		V																																													
Astra-F	Body	Airbag-S	V	V		V																																													
Astra-G	Engine	C 16 SEL	V			V																																													
Astra-G	Engine	C 18 NE	V	V	V	V																																													
Astra-G	Engine	C 18 YE	V	V	V	V																																													
Astra-G	Engine	C 20 NE/C 20 SE(8V)	V	V	V	V																																													
Astra-G	Engine	X 12 XE	V			V																																													
Astra-G	Engine	X 14 XE	V			V																																													
Astra-G	Engine	X 16 SZR	V	V	V	V																																													
Astra-G	Engine	X 16 XEL	V	V	V	V																																													
Astra-G	Engine	X 17 DTL	V	V	V	V																																													
Astra-G	Engine	X 18 XE1	V	V	V	V			V	V		V	V																																						
Astra-G	Engine	X 20 DTL	V	V	V	V																																													
Astra-G	Engine	X 20 XER	V			V																																													
Astra-G	Engine	X 20 XEV	V	V	V	V																																													
Astra-G	Engine	X 24 SE	V	V	V	V																																													
Astra-G	Engine	Y 17 DT	V	V	V	V																																													
Astra-G	Engine	Y 20 DTH	V	V	V	V																																													
Astra-G	Engine	Y 20 DTL	V			V																																													
Astra-G	Engine	Y 22 DTR	V	V	V	V																																													
Astra-G	Engine	Z 12 XE	V	V	V	V																																													
Astra-G	Engine	Z 14 XE	V	V	V	V																																													
Astra-G	Engine	Z 14 XEP	V			V																																													
Astra-G	Engine	Z 16 SE	V	V	V	V																																													
Astra-G	Engine	Z 16 XE	V	V	V	V																																													

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	Program CAN configuration	Injector Cutoff Test	Adjust idle speed	Adjust idle drive	Idle air control	RPM control	Injector Cutoff	Reset TC signal status	Reset learned values	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Reset TC signal status	Calibration	Steering angle sensor calibration	Program transponder key	Erase transponder key	Reset Immobilizer	Program Immobilizer output	Reset service interval	Erase remote keys	Program remote key	Reset body control module	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Reset IAC block learn map	Reset ECU	Fuel pump relay test	Program tyre circumference	Bleed clutch hydraulic	Learn gearbox parameters	Touch point adaptation	Additional Touch Point Adaption	Clutch control test	Read security PIN code	BCM link to ECM/Immobilizer	Idle Test	Fuel Correction Test	Service Regeneration
Astra-G	Engine	Z 16 XEP	V	V	V	V																																													
Astra-G	Engine	Z 16 YNG	V			V																																													
Astra-G	Engine	Z 17 DTL	V			V																																													
Astra-G	Engine	Z 18 XE	V	V	V	V						V	V			V	V	V	V																																
Astra-G	Engine	Z 18 XEL	V			V																																													
Astra-G	Engine	Z 20 LET	V	V	V	V																																													
Astra-G	Engine	Z 22 SE	V	V	V	V												V	V	V	V	V																													
Astra-G	Transmission	AF 13-II/17/20/22	V	V	V	V																	V																													
Astra-G	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																													
Astra-G	Chassis	ABS-5.3/5.4 (+TC)	V	V	V	V																																													
Astra-G	Chassis	ESP	V	V	V																				V																										
Astra-G	Chassis	Electronic Power Steering	V	V	V																																														
Astra-G	Body	Immobiliser	V	V		V																				V	V	V	V																							
Astra-G	Body	Airbag SAB6	V	V		V																																													
Astra-G	Body	Airbag	V	V		V																																													
Astra-G	Body	Instrument	V	V	V	V																								V																						
Astra-G	Body	Engine Cooling Module	V	V		V																																													
Astra-G	Body	Central Door Lock	V	V	V	V																									V	V																				
Astra-G	Body	Add On Heater	V	V	V																																														
Astra-G	Body	Softtop Controller	V	V	V																																														
Astra-G	Body	Electronic Climate Control	V	V		V																																													
Astra-G	Body	Headlamp Levelling Device	V	V	V																																														
Astra-G	Infotainment System	Triple Info Display	V	V	V	V																																													
Astra-G	Infotainment System	Multi Info Display	V	V	V	V																																													
Astra-G	Infotainment System	Read security PIN code(Beta)																																												V					
Corsa-B	Engine	C 14 NE	V	V	V																																														
Corsa-B	Engine	C 16 NE	V	V	V																																														
Corsa-B	Engine	16 NE	V	V	V																																														
Corsa-B	Engine	C 14 SE	V	V	V	V																																													
Corsa-B	Engine	Z 14 XE	V	V	V	V	V	V										V	V			V												V																	
Corsa-B	Engine	Z 14 XEP	V	V	V	V		V				V			V	V			V	V		V																													
Corsa-B	Engine	Z 16 SE	V	V	V	V		V										V	V			V																													
Corsa-B	Engine	Z 18 XE	V	V	V	V	V					V	V			V	V	V	V																																
Corsa-B	Transmission	AF 13/14/20	V	V	V	V																																													
Corsa-B	Transmission	AF 13II/20/22/30	V	V	V	V								V	V																																				
Corsa-B	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																													
Corsa-B	Chassis	ABS 5.3/5.4 +TC	V	V	V	V																																													
Corsa-B	Chassis	ABS/ESP8	V	V	V	V																																													
Corsa-B	Chassis	Electronic Power Steering	V	V		V																			V																										
Corsa-B	Body	Body Control Module	V	V	V	V																									V	V	V														V				
Corsa-B	Body	Immobiliser	V	V		V																				V	V	V	V																						
Corsa-B	Body	Airbag	V	V		V																												V	V	V															

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	Program CAN configuration	Injector Cutoff Test	Adjust idle speed	Adjust idle drive	Idle air control	RPM control	Injector Cutoff	Reset TC signal status	Reset learned values	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Reset TC signal status	Calibration	Steering angle sensor calibration	Program transponder key	Erase transponder key	Reset Immobilizer	Program Immobilizer output	Reset service interval	Erase remote keys	Program remote key	Reset body control module	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Reset IAC block learn map	Reset ECU	Fuel pump relay test	Program tyre circumference	Bleed clutch hydraulic	Learn gearbox parameters	Touch point adaptation	Additional Touch Point Adaption	Clutch control test	Read security PIN code	BCM link to ECM/Immobilizer	Idle Test	Fuel Correction Test	Service Regeneration
Corsa-B	Body	Instrument	V	V	V	V																																													
Corsa-B	Infotainment System	Triple Info Display	V	V	V	V																								V																					
Corsa-C	Engine	C 10 NE(E0/E20)	V	V	V	V																																													
Corsa-C	Engine	C 10 YE(E100)	V	V	V	V																																													
Corsa-C	Engine	C 10 YEH(E0 E20)	V	V	V	V																																													
Corsa-C	Engine	C 16 SE	V	V	V	V																																													
Corsa-C	Engine	C 18 XE	V	V	V	V																																													
Corsa-C	Engine	X 18 NXE	V	V	V	V																																													
Corsa-C	Engine	C 14 SE	V	V	V	V																																													
Corsa-C	Engine	C 14 NE	V	V	V	V																																													
Corsa-C	Engine	C 18 NE	V	V	V	V																																													
Corsa-C	Engine	Y 17 DT	V	V	V	V																																													
Corsa-C	Engine	Y 17 DTL	V	V	V	V																																													
Corsa-C	Engine	Y 13 DT	V			V																																													
Corsa-C	Engine	Z 10 XE	V			V																																													
Corsa-C	Engine	Z 12 XE	V	V	V	V																																													
Corsa-C	Engine	Z 14 XE	V	V	V	V	V	V										V	V			V												V																	
Corsa-C	Engine	Z 18 XE	V	V	V	V						V	V			V	V	V	V																																
Corsa-C	Engine	Z 16 SE	V	V	V	V		V										V	V			V																													
Corsa-C	Engine	Z 10 XEP	V	V	V	V		V				V				V	V		V	V		V																													
Corsa-C	Engine	Z 13 DT	V			V																																													
Corsa-C	Engine	Z 14 XEP	V	V	V	V		V				V				V	V		V	V		V																													
Corsa-C	Engine	Z 17 DTH	V	V	V	V																																													
Corsa-C	Engine	Z 12 XEP	V			V																																													
Corsa-C	Engine	Z 16 YNG	V			V																																													
Corsa-C	Engine	Z 13 DTJ	V	V	V	V																																													
Corsa-C	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																													
Corsa-C	Transmission	MTA (Easytronic)	V	V	V	V																																			V	V	V	V	V						
Corsa-C	Chassis	ABS-5.3/5.4 (+TC)	V	V	V	V																																													
Corsa-C	Chassis	ABS8/ESP8	V	V	V	V																																													
Corsa-C	Chassis	Electronic Power Steering	V	V	V	V																		V																											
Corsa-C	Body	Body Control Module	V	V	V	V																									V	V	V															V			
Corsa-C	Body	Immobiliser	V	V		V																				V	V	V	V																						
Corsa-C	Body	Airbag	V	V		V																												V	V	V															
Corsa-C	Body	Instrument	V	V	V	V																								V																					
Corsa-C	Body	Add On Heater	V	V	V																																														
Corsa-C	Body	Headlamp Levelling Device	V	V	V																																														
Corsa-C	Infotainment System	Triple Info Display	V	V	V	V																																													
Corsa-C	Infotainment System	Read security PIN code(Beta)																																												V					
Omega-B	Engine	20 SE	V			V																																													
Omega-B	Engine	X 20 SE	V			V																																													
Omega-B	Engine	X 20 XEV	V			V																																													

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	Program CAN configuration	Injector Cutoff Test	Adjust idle speed	Adjust idle drive	Idle air control	RPM control	Injector Cutoff	Reset TC signal status	Reset learned values	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Reset TC signal status	Calibration	Steering angle sensor calibration	Program transponder key	Erase transponder key	Reset Immobilizer	Program Immobilizer output	Reset service interval	Erase remote keys	Program remote key	Reset body control module	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Reset IAC block learn map	Reset ECU	Fuel pump relay test	Program tyre circumference	Bleed clutch hydraulic	Learn gearbox parameters	Touch point adaptation	Additional Touch Point Adaption	Clutch control test	Read security PIN code	BCM link to ECM/Immobilizer	Idle Test	Fuel Correction Test	Service Regeneration
Omega-B	Engine	X 25 DT	V			V																																													
Omega-B	Engine	X 25 XE	V			V																																													
Omega-B	Engine	X 30 XE	V			V																																													
Omega-B	Engine	X 20 DTH	V			V																																													
Omega-B	Engine	Y 22 XE	V			V																																													
Omega-B	Engine	Y 22 DTH	V			V																																													
Omega-B	Engine	Y 26 SE	V			V																																													
Omega-B	Engine	Y 32 SE	V			V																																													
Omega-B	Engine	Y 25 DT	V			V																																													
Omega-B	Engine	Z 22 XE	V			V																																													
Omega-B	Transmission	AR 25/35	V			V																																													
Omega-B	Transmission	5L40-E	V			V																																													
Omega-B	Chassis	ABS-5.3/5.4 (+TC)	V	V	V	V																																													
Omega-B	Chassis	ESP	V			V																																													
Omega-B	Body	Immobiliser	V	V		V																				V	V	V	V																						
Omega-B	Body	Airbag-S	V	V		V																																													
Omega-B	Body	Airbag SAB6	V	V		V																																													
			V			V																																													
Omega-B	Body	Airbag	V	V		V																																													
			V			V																																													
Omega-B	Body	Add On Heater	V	V	V																																														
Omega-B	Body	Headlamp Levelling Device	V	V	V	V																																													
Omega-B	Infotainment System	Triple Info Display	V	V	V	V																																													
Omega-B	Infotainment System	Multi Info Display	V	V	V	V																																													
Tigra-B	Engine	Z 13 DT	V			V																																													
Tigra-B	Engine	C 14 SE	V	V	V	V																																													
Tigra-B	Engine	Z 14 XE	V	V	V	V	V	V										V	V			V												V																	
Tigra-B	Engine	Z 14 XEP	V	V	V	V		V				V			V	V			V	V		V																													
Tigra-B	Engine	Z 16 SE	V	V	V	V		V										V	V			V																													
Tigra-B	Engine	Z 18 XE	V	V	V	V	V	V				V				V	V	V	V															V																	
Tigra-B	Transmission	MTA (Easytronic)	V			V																																													
Tigra-B	Transmission	AF 13/14/20	V	V	V	V																																													
Tigra-B	Transmission	AF 13II/20/22/30	V	V	V	V											V						V																												
Tigra-B	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																													
Tigra-B	Chassis	ABS8/ESP8	V	V		V																																													
Tigra-B	Chassis	ABS 5.3/5.4 +TC	V	V	V	V																																													
Tigra-B	Chassis	Electronic Power Steering	V	V		V																		V																											
Tigra-B	Body	Body Control Module	V	V	V	V																									V	V	V															V			
Tigra-B	Body	Immobiliser	V	V		V																				V	V	V	V																						
Tigra-B	Body	Airbag	V	V		V																												V	V	V															
Tigra-B	Body	Instrument	V	V	V	V																								V																					
Tigra-B	Body	Electrohydraulic Hardtop	V			V																																													

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	Program CAN configuration	Injector Cutoff Test	Adjust idle speed	Adjust idle drive	Idle air control	RPM control	Injector Cutoff	Reset TC signal status	Reset learned values	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Reset TC signal status	Calibration	Steering angle sensor calibration	Program transponder key	Erase transponder key	Reset Immobilizer	Program Immobilizer output	Reset service interval	Erase remote keys	Program remote key	Reset body control module	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Reset IAC block learn map	Reset ECU	Fuel pump relay test	Program tyre circumference	Bleed clutch hydraulic	Learn gearbox parameters	Touch point adaptation	Additional Touch Point Adaption	Clutch control test	Read security PIN code	BCM link to ECM/Immobilizer	Idle Test	Fuel Correction Test	Service Regeneration
Tigra-B	Infotainment System	Read security PIN code(Beta)																																												V				
Vectra-B	Engine	16 LZ 2	V			V																																													
Vectra-B	Engine	20 NEJ	V			V																																													
Vectra-B	Engine	C 20 SEL	V	V	V	V			V	V			V																																						
Vectra-B	Engine	C 22 SEL	V	V	V	V			V		V	V	V																																						
Vectra-B	Engine	X 16 SZR	V	V	V	V																																													
Vectra-B	Engine	X 16 XEL	V	V	V	V																																													
Vectra-B	Engine	X 18 XE	V	V	V	V																																													
Vectra-B	Engine	X 18 XE1	V	V	V	V																																													
Vectra-B	Engine	X 20 DTL	V	V	V	V																																													
Vectra-B	Engine	X 20 XEV	V	V	V	V																																													
Vectra-B	Engine	X 25 XE	V	V	V	V			V											V																	V														
Vectra-B	Engine	X 20 DTH	V	V	V	V																																													
Vectra-B	Engine	Y 16 XE	V			V																																													
Vectra-B	Engine	Y 20 DTH	V			V																																													
Vectra-B	Engine	Y 22 DTR	V			V																																													
Vectra-B	Engine	Y 26 SE	V	V	V	V																																													
Vectra-B	Engine	Z 16 XE	V	V	V	V																																													
Vectra-B	Engine	Z 18 XE	V			V																																													
Vectra-B	Engine	Z 18 XEL	V			V																																													
Vectra-B	Engine	Z 22 SE	V	V	V	V																																													
Vectra-B	Transmission	AF 13II/20/22/30	V	V	V	V											V						V																												
Vectra-B	Transmission	AF 13-II/17/20/22	V	V	V	V																	V																												
Vectra-B	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																													
Vectra-B	Chassis	ABS 430	V	V	V	V																																													
Vectra-B	Chassis	ABS-5.3/5.4 (+TC)	V	V	V	V																																													
Vectra-B	Body	Immobiliser	V	V		V																				V	V	V	V																						
Vectra-B	Body	Airbag	V	V		V																																													
Vectra-B	Body	Airbag SAB6	V	V		V																																													
Vectra-B	Body	Instrument	V	V		V																																													
Vectra-B	Body	Add On Heater	V	V	V	V																																													
Vectra-B	Body	Central Door Lock	V	V	V	V																									V	V																			
Vectra-B	Body	Headlamp Levelling Device(Left)	V	V		V																																													
Vectra-B	Body	Headlamp Levelling Device(Right)	V	V																																															
Vectra-B	Infotainment System	Triple Info Display	V	V	V	V																																													
Vectra-B	Infotainment System	Read security PIN code(Beta)																																												V					
Zafira	Engine	X 16 XEL	V	V	V	V																																													
Zafira	Engine	X 18 XE1	V	V	V	V																																													
Zafira	Engine	C 20 SEL	V	V	V	V																																													
Zafira	Engine	X 20 DTL	V	V	V	V																																													
Zafira	Engine	Y 20 DTH	V	V	V	V																																													
Zafira	Engine	Y 22 DTR	V	V	V	V																																													

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	Program CAN configuration	Injector Cutoff Test	Adjust idle speed	Adjust idle drive	Idle air control	RPM control	Injector Cutoff	Reset TC signal status	Reset learned values	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Reset TC signal status	Calibration	Steering angle sensor calibration	Program transponder key	Erase transponder key	Reset Immobilizer	Program Immobilizer output	Reset service interval	Erase remote keys	Program remote key	Reset body control module	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Reset IAC block learn map	Reset ECU	Fuel pump relay test	Program tyre circumference	Bleed clutch hydraulic	Learn gearbox parameters	Touch point adaptation	Additional Touch Point Adaption	Clutch control test	Read security PIN code	BCM link to ECM/Immobilizer	Idle Test	Fuel Correction Test	Service Regeneration
Zafira	Engine	Z 16 XE	V	V	V	V																																													
Zafira	Engine	Z 16 YNG	V			V																																													
Zafira	Engine	Z 18 XE	V			V																																													
Zafira	Engine	Z 22 SE	V	V	V	V												V	V	V	V	V																													
Zafira	Engine	C 20 SE	V	V	V	V																																													
Zafira	Engine	Z 20 LET	V	V	V	V																																													
Zafira	Transmission	AF 13-II/17/20/22	V			V																																													
Zafira	Transmission	AF 13-II/17/20/22 CAN	V	V	V	V																																													
Zafira	Chassis	ABS-5.3/5.4 (+TC)	V	V		V																																													
Zafira	Chassis	ESP	V	V																																															
Zafira	Chassis	Electronic Power Steering	V	V	V																																														
Zafira	Body	Airbag SAB6	V	V		V																																													
Zafira	Body	Airbag	V	V		V																																													
Zafira	Body	Instrument	V	V	V	V																								V																						
Zafira	Body	Engine Cooling Module	V	V		V																																													
Zafira	Body	Central Door Lock	V	V	V	V																									V	V																				
Zafira	Body	Headlamp Levelling Device(Left)	V	V																																															
Zafira	Body	Headlamp Levelling Device(Right)	V	V																																															
Zafira	Infotainment System	Triple Info Display	V	V	V	V																																													
Zafira	Infotainment System	Read security PIN code(Beta)																																												V					
Meriva	Engine	Y 13 DT	V			V																																													
Meriva	Engine	Z 13 DTJ	V			V																																													
Meriva	Engine	Z 14 XEP	V			V																																													
Meriva	Engine	Z 16 LET	V			V																																													
Meriva	Engine	Z 16 SE	V			V																																													
Meriva	Engine	Z 16 XE	V	V	V	V																																													
Meriva	Engine	Z 16 XEP	V			V																																													
Meriva	Engine	Y 17 DT	V			V																																													
Meriva	Engine	Z 17 DT	V			V																																													
Meriva	Engine	Z 17 DTH	V			V																																													
Meriva	Engine	Z 17 DTR	V			V																																													
Meriva	Engine	Z 18 XE	V			V																																													
Meriva	Transmission	MTA (Easytronic)	V	V	V	V																																			V	V	V	V	V						
Meriva	Chassis	ABS	V	V	V	V																																													
Meriva	Chassis	Electronic Power Steering	V	V	V	V																		V																											
Meriva	Body	Body Control Module	V	V	V	V																									V	V	V															V			
Meriva	Infotainment System	Read security PIN code(Beta)																																												V					
Captiva/Antara Long Body	Powertrain	ECM(DIESEL)	V	V	V	V																																											V	V	V
Captiva/Antara Long Body	Powertrain	ECM(2.4D)	V	V	V	V																																													
Captiva/Antara Long Body	Powertrain	ECM(3.2D)	V	V	V	V																																													
Captiva/Antara Long Body	Powertrain	TCM	V	V	V	V									V																																				
Captiva/Antara Long Body	Chassis	Electronic Brake Control Module	V	V	V	V																			V																											

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	Program CAN configuration	Injector Cutoff Test	Adjust idle speed	Adjust idle drive	Idle air control	RPM control	Injector Cutoff	Reset TC signal status	Reset learned values	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Reset TC signal status	Calibration	Steering angle sensor calibration	Program transponder key	Erase transponder key	Reset Immobilizer	Program Immobilizer output	Reset service interval	Erase remote keys	Program remote key	Reset body control module	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Reset IAC block learn map	Reset ECU	Fuel pump relay test	Program tyre circumference	Bleed clutch hydraulic	Learn gearbox parameters	Touch point adaptation	Additional Touch Point Adaption	Clutch control test	Read security PIN code	BCM link to ECM/Immobilizer	Idle Test	Fuel Correction Test	Service Regeneration
Captiva/Antara Long Body	Chassis	Transfer Case Control Module	V	V	V																																														
Captiva/Antara Long Body	Body	SDM(SRSAirbag)	V	V																																															
Captiva/Antara Long Body	Body	Instrument Panel Cluster	V	V	V	V																																													
Captiva/Antara Long Body	Body	Body Control Module	V	V	V	V																																													
Captiva/Antara Long Body	Body	Theft Deterrent Module	V	V		V																																													
Captiva/Antara Long Body	Body	Remote Function Actuator	V	V		V																																													
Captiva/Antara Short Body	Engine	2.0 L (Diesel)	V	V	V	V																																													
Captiva/Antara Short Body	Engine	Z 24 XE	V			V																																													
Captiva/Antara Short Body	Engine	Z 32 SE	V	V	V	V																																													
Captiva/Antara Short Body	Transmission	Automatic Transmission	V	V	V	V																																													
Captiva/Antara Short Body	Transmission	TCCM (Transfer Case Control Module)	V	V		V																																													
Captiva/Antara Short Body	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	V	V	V	V																																													
Captiva/Antara Short Body	Body	Immobiliser	V			V																																													
Captiva/Antara Short Body	Body	IPC (Instrument)	V	V	V	V																																													
Captiva/Antara Short Body	Body	Central Door Lock	V	V	V																																														
Captiva/Antara Short Body	Body	Anti Theft Warning System	V	V	V																																														
Captiva/Antara Short Body	Body	Wipers/Washer	V	V		V																																													
Captiva/Antara Short Body	Body	Interior Lighting	V	V																																															
Captiva/Antara Short Body	Body	Exterior Lighting/Turn Indicator System	V	V		V																																													
Captiva/Antara Short Body	Body	SDM (Airbag)	V	V		V																																													
Captiva/Antara Short Body	Body	ECC (Electronic Climate Control)	V		V	V																																													
Captiva/Antara Short Body	Body	PAS (Park Pilot)	V	V		V																																													
Captiva/Antara Short Body	Body	BCM (Body Control Module)	V	V		V																																													
Captiva/Antara Short Body	Body	RFA (Multipurpose Receiver Module)	V	V		V																																													
Captiva/Antara Short Body	Body	HVAC (Heating Ventilation and Cooling)	V	V		V																																													
Captiva/Antara Short Body	Body	SLM (Shift Lever Module)	V	V		V																																													
Captiva/Antara Short Body	Body	XBCM (Auxiliary Body Control Module)	V			V																																													
Astra-H	Engine	A 16 LET	V			V																																													
Astra-H	Engine	A 16 XER	V			V																																													
Astra-H	Engine	A 17 DTJ	V			V																																													
Astra-H	Engine	A 17 DTR	V			V																																													
Astra-H	Engine	A 18 XER	V			V																																													
Astra-H	Engine	Y 13 DTH	V			V																																													
Astra-H	Engine	Z 14 XEP	V	V	V	V																																													
Astra-H	Engine	Z 16 XEP	V			V																																													
Astra-H	Engine	Z 17 DTH	V	V	V	V																																													
Astra-H	Engine	Z 17 DTL	V			V																																													
Astra-H	Engine	Z 18 XE	V	V	V	V		V											V																				V	V												
Astra-H	Engine	Z 20 LEL	V			V																																													
Astra-H	Engine	Z 20 LER	V	V	V	V													V	V																			V	V												
Astra-H	Engine	Z 13 DTH	V			V																																													
Astra-H	Engine	Z 19 DTH	V			V																																													

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	Program CAN configuration	Injector Cutoff Test	Adjust idle speed	Adjust idle drive	Idle air control	RPM control	Injector Cutoff	Reset TC signal status	Reset learned values	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Reset TC signal status	Calibration	Steering angle sensor calibration	Program transponder key	Erase transponder key	Reset Immobilizer	Program Immobilizer output	Reset service interval	Erase remote keys	Program remote key	Reset body control module	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Reset IAC block learn map	Reset ECU	Fuel pump relay test	Program tyre circumference	Bleed clutch hydraulic	Learn gearbox parameters	Touch point adaptation	Additional Touch Point Adaption	Clutch control test	Read security PIN code	BCM link to ECM/Immobilizer	Idle Test	Fuel Correction Test	Service Regeneration
Astra-H	Engine	Z 20 LEH	V	V	V	V														V																			V												
Astra-H	Engine	Z 12 XEP	V			V																																													
Astra-H	Engine	Z 14 XEL	V			V																																													
Astra-H	Engine	Z 18 XER	V	V	V	V		V							V				V																				V	V											
Astra-H	Engine	Z 19 DT	V	V	V	V																																	V	V											
Astra-H	Engine	Z 16 LET	V			V																																													
Astra-H	Engine	Z 16 XE1	V			V																																													
Astra-H	Engine	Z 16 XER	V	V	V	V																																													
Astra-H	Engine	Z 17 DTJ	V			V																																													
Astra-H	Engine	Z 17 DTR	V			V																																													
Astra-H	Engine	Z 22 YH	V	V	V	V													V																				V	V											
Astra-H	Transmission	AF 17-4	V	V	V	V									V																							V													
Astra-H	Transmission	MTA (Easytronic)	V			V																																													
Astra-H	Transmission	AF 40-6	V	V	V	V									V																																				
Astra-H	Transmission	MTA (Easytronic Magneti Marelli)	V			V																																													
Astra-H	Transmission	AF 22-4	V	V	V	V									V																							V													
Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	V	V	V	V																																													
Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	V			V																																													
Astra-H	Chassis	ABS/TC/ESP ECU (Electronic Control Unit)	V	V	V	V																																													
Astra-H	Chassis	TPMS ECU (Tyre Pressure Monitoring)	V	V		V																																													
Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)	V	V		V																																													
Astra-H	Chassis	CDC (Continuous Damping Control)	V	V	V	V																																													
Astra-H	Body	Instrument	V			V																																													
Astra-H	Body	Exterior Lighting/Turn Indicator System	V			V																																													
Astra-H	Body	IPC ECU (Instrument Control Unit)	V	V	V	V																																													
Astra-H	Body	SDM (Airbag)	V	V		V																														V															
Astra-H	Body	AHL/AFL (Headlamp Levelling)	V	V	V	V																																													
Astra-H	Body	PAS (Park Pilot)	V	V		V																																													
Astra-H	Body	EHS (Electrical Heater System)	V	V		V																																													
Astra-H	Body	CIM (Steering Column Module)	V	V	V	V																			V	V	V																								
Astra-H	Body	REC (Rear Electrical Centre)	V	V	V	V																																													
Astra-H	Body	UEC (Underhood Electrical Centre)	V	V	V	V																																													
Astra-H	Body	PEPS (Open/Start)	V	V		V																																													
Astra-H	Body	Electrohydraulic Hardtop	V	V	V	V																																													
Astra-H	Body	ECC/SAC (Electronic Climate Control)	V	V	V	V																																													
Astra-H	Body	SLM (Shift Lever Module)	V	V	V	V																																													
Corsa-D	Engine	A 10 XEP	V			V																																													
Corsa-D	Engine	A 12 XEL	V			V																																													
Corsa-D	Engine	A 12 XER	V			V																																													
Corsa-D	Engine	A 13 DTR	V			V																																													
Corsa-D	Engine	A 13 DTC	V			V																																													
Corsa-D	Engine	A 13 DTE	V			V																																													

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	Program CAN configuration	Injector Cutoff Test	Adjust idle speed	Adjust idle drive	Idle air control	RPM control	Injector Cutoff	Reset TC signal status	Reset learned values	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Reset TC signal status	Calibration	Steering angle sensor calibration	Program transponder key	Erase transponder key	Reset Immobilizer	Program Immobilizer output	Reset service interval	Erase remote keys	Program remote key	Reset body control module	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Reset IAC block learn map	Reset ECU	Fuel pump relay test	Program tyre circumference	Bleed clutch hydraulic	Learn gearbox parameters	Touch point adaptation	Additional Touch Point Adaption	Clutch control test	Read security PIN code	BCM link to ECM/Immobilizer	Idle Test	Fuel Correction Test	Service Regeneration
Corsa-D	Engine	A 14 XEL	V			V																																													
Corsa-D	Engine	A 14 XER	V			V																																													
Corsa-D	Engine	A 16 LEL	V			V																																													
Corsa-D	Engine	A 16 LER	V			V																																													
Corsa-D	Engine	A 17 DTS	V			V																																													
Corsa-D	Engine	Z 10 XEP	V			V																																													
Corsa-D	Engine	Z 12 XEP	V	V	V	V																																													
Corsa-D	Engine	Z 13 DTE	V			V																																													
Corsa-D	Engine	Z 13 DTH	V			V																																													
Corsa-D	Engine	Z 13 DTJ	V			V																																													
Corsa-D	Engine	Z 14 XEP	V			V																																													
Corsa-D	Engine	Z 16 LER	V			V																																													
Corsa-D	Engine	Z 17 DTR	V			V																																													
Corsa-D	Engine	Z 16 LEL	V			V																																													
Corsa-D	Transmission	AF 13-4	V	V	V	V																																													
Corsa-D	Transmission	MTA (Easytronic)	V	V	V	V																																													
Corsa-D	Transmission	MTA (Easytronic Magneti Marelli)	V	V	V	V																																													
Corsa-D	Chassis	ABS/ESP	V	V	V	V																																													
Corsa-D	Chassis	Electronic Power Steering	V	V		V																																													
Corsa-D	Body	AFL (Adaptive Forward Lighting)	V	V	V	V																																													
Corsa-D	Body	TIM (Trailer Interface Module)	V	V	V	V																																													
Corsa-D	Body	Immobiliser	V			V																																													
Corsa-D	Body	IPC (Instrument)	V	V	V	V																																													
Corsa-D	Body	Central Door Lock	V			V																																													
Corsa-D	Body	Anti Theft Warning System	V			V																																													
Corsa-D	Body	Heating Ventilation and Air Cond.	V			V																																													
Corsa-D	Body	Wipers/Washer	V			V																																													
Corsa-D	Body	Interior Lighting	V			V																																													
Corsa-D	Body	Exterior Lighting	V			V																																													
Corsa-D	Body	SDM (Airbag)	V	V		V																																													
Corsa-D	Body	PAS (Park Pilot)	V	V		V																																													
Corsa-D	Body	EHS (Electrical Heater System)	V	V	V	V																																													
Corsa-D	Body	BCM (Body Control Module)	V			V																																													
Corsa-D	Body	Stop/Start System	V			V																																													
Vectra-C	Engine	Engine Cooling	V	V																																															
Vectra-C	Engine	Y 20 DTH	V			V																																													
Vectra-C	Engine	Y 22 DTR	V			V																																													
Vectra-C	Engine	Y 30 DT	V			V																																													
Vectra-C	Engine	Z 16 XE	V			V																																													
Vectra-C	Engine	Z 16 XEP	V			V																																													
Vectra-C	Engine	Z 18 XE	V			V																																													
Vectra-C	Engine	Z 18 XER	V			V																																													

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	Program CAN configuration	Injector Cutoff Test	Adjust idle speed	Adjust idle drive	Idle air control	RPM control	Injector Cutoff	Reset TC signal status	Reset learned values	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Reset TC signal status	Calibration	Steering angle sensor calibration	Program transponder key	Erase transponder key	Reset Immobilizer	Program Immobilizer output	Reset service interval	Erase remote keys	Program remote key	Reset body control module	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Reset IAC block learn map	Reset ECU	Fuel pump relay test	Program tyre circumference	Bleed clutch hydraulic	Learn gearbox parameters	Touch point adaptation	Additional Touch Point Adaption	Clutch control test	Read security PIN code	BCM link to ECM/Immobilizer	Idle Test	Fuel Correction Test	Service Regeneration
Vectra-C	Engine	Z 19 DT	V	V	V	V																																													
Vectra-C	Engine	Z 19 DTH	V			V																																													
Vectra-C	Engine	Z 20 NET	V			V																																													
Vectra-C	Engine	Z 22 SE	V			V																																													
Vectra-C	Engine	Z 22 YH	V			V																																													
Vectra-C	Engine	Z 28 NEH	V			V																																													
Vectra-C	Engine	Z 28 NEL	V			V																																													
Vectra-C	Engine	Z 28 NET	V			V																																													
Vectra-C	Engine	Z 30 DT	V			V																																													
Vectra-C	Engine	Z 32 SE	V	V	V	V		V																															V	V											
Vectra-C	Transmission	AF 23-5/33-5/40-6	V	V	V	V									V																							V													
Vectra-C	Transmission	MTA (Easytronic)	V			V																																													
Vectra-C	Transmission	CVTronic	V			V																																													
Vectra-C	Transmission	AF 23-5/33-5	V			V																																													
Vectra-C	Chassis	ABS/TC/ESP	V	V		V																																													
Vectra-C	Chassis	TPMS (Tyre Pressure Monitoring System)	V			V																																													
Vectra-C	Chassis	Electronic Cruise Control	V			V																																													
Vectra-C	Chassis	EHPS (Electrohydraulic Power Steering)	V	V		V																																													
Vectra-C	Chassis	CDC (Continuous Damping Control)	V	V	V	V																																													
Vectra-C	Body	Immobiliser	V			V																																													
Vectra-C	Body	IPC(Instrument)	V			V																																													
Vectra-C	Body	Central Door Lock	V			V																																													
Vectra-C	Body	Anti Theft Warning System	V	V		V																																													
Vectra-C	Body	Heating Ventilation and Air Cond.	V	V		V																																													
Vectra-C	Body	Additional Heating	V			V																																													
Vectra-C	Body	Electronic Seat Memory/Seat Heating	V			V																																													
Vectra-C	Body	Wipers/Washer	V			V																																													
Vectra-C	Body	Turn Indication	V			V																																													
Vectra-C	Body	Interior Lighting	V			V																																													
Vectra-C	Body	Exterior Lighting	V			V																																													
Vectra-C	Body	Power Window Lifter	V	V		V																																													
Vectra-C	Body	Electric Adjustable Mirrors	V			V																																													
Vectra-C	Body	SDM (Airbag; Sensing/Diagnostic Module)	V	V		V																																													
Vectra-C	Body	SRM (Sun Roof Module)	V	V		V																																													
Vectra-C	Body	ECC (Electronic Climate Control)	V	V		V																																													
Vectra-C	Body	SAC (Automatic Climate Control)	V			V																																													
Vectra-C	Body	AHL/AFL (Headlamp Levelling)	V	V	V	V																																													
Vectra-C	Body	Electrical Horn	V			V																																													
Vectra-C	Body	PAS (Park Pilot)	V			V																																													
Vectra-C	Body	EHS (Electrical Heater System)	V	V	V	V																																													
Vectra-C	Body	CIM (Steering Column Module)	V			V																																													
Vectra-C	Body	BCM (Body Control Module)	V	V		V																																													

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	Program CAN configuration	Injector Cutoff Test	Adjust idle speed	Adjust idle drive	Idle air control	RPM control	Injector Cutoff	Reset TC signal status	Reset learned values	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Reset TC signal status	Calibration	Steering angle sensor calibration	Program transponder key	Erase transponder key	Reset Immobilizer	Program Immobilizer output	Reset service interval	Erase remote keys	Program remote key	Reset body control module	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Reset IAC block learn map	Reset ECU	Fuel pump relay test	Program tyre circumference	Bleed clutch hydraulic	Learn gearbox parameters	Touch point adaptation	Additional Touch Point Adaption	Clutch control test	Read security PIN code	BCM link to ECM/Immobilizer	Idle Test	Fuel Correction Test	Service Regeneration
Vectra-C	Body	REC (Rear Electrical Centre)	V	V		V																																													
Vectra-C	Body	UEC (Underhood Electrical Centre)	V	V		V																																													
Vectra-C	Body	DDM (Driver Door Module)	V			V																																													
Vectra-C	Body	PDM (Passenger Door Module)	V			V																																													
Vectra-C	Body	SLM (Shift Lever Module)	V	V		V																																													
Zafira-B	Engine	Z 16 XEP	V			V																																													
Zafira-B	Engine	Z 18 XER	V			V																																													
Zafira-B	Engine	Z 19 DT	V			V																																													
Zafira-B	Engine	Z 19 DTH	V			V																																													
Zafira-B	Engine	Z 20 LER	V			V																																													
Zafira-B	Engine	Z 22 YH	V			V																																													
Zafira-B	Engine	Z 16 YNG	V			V																																													
Zafira-B	Engine	Z 20 LEH	V			V																																													
Zafira-B	Engine	Z 16 XE1	V			V																																													
Zafira-B	Engine	Z 16 XER	V			V																																													
Zafira-B	Engine	Z 16 XNT	V			V																																													
Zafira-B	Engine	Z 17 DTJ	V			V																																													
Zafira-B	Engine	A 16 XER	V			V																																													
Zafira-B	Engine	A 16 XNT	V			V																																													
Zafira-B	Engine	A 17 DTJ	V			V																																													
Zafira-B	Engine	A 17 DTR	V			V																																													
Zafira-B	Engine	A 18 XER	V			V																																													
Zafira-B	Transmission	AF 40-6	V			V																																													
Zafira-B	Transmission	AF 22-4	V			V																																													
Zafira-B	Transmission	MTA (Easytronic)	V			V																																													
Zafira-B	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	V	V	V	V																																													
Zafira-B	Chassis	TPMS (Tyre Pressure Monitoring System)	V			V																																													
Zafira-B	Chassis	ABS/TC/ESP ECU (Electronic Control Unit)	V	V	V	V																																													
Zafira-B	Chassis	TPMS ECU (Tyre Pressure Monitoring)	V	V		V																																													
Zafira-B	Chassis	EHPS (Electrohydraulic Power Steering)	V			V																																													
Zafira-B	Chassis	CDC (Continuous Damping Control)	V	V	V	V																																													
Zafira-B	Body	PEPS (Open/Start)	V	V		V																																													
Zafira-B	Body	Immobiliser	V	V		V																																													
Zafira-B	Body	Instrument	V	V		V																																													
Zafira-B	Body	Central Door Lock	V	V		V																																													
Zafira-B	Body	Anti Theft Warning System	V	V		V																																													
Zafira-B	Body	Wipers/Washer	V	V		V																																													
Zafira-B	Body	Interior Lighting	V	V		V																																													
Zafira-B	Body	Exterior Lighting/Turn Indicator System	V	V		V																																													
Zafira-B	Body	IPC ECU (Instrument Control Unit)	V	V	V	V																																													
Zafira-B	Body	SDM (Airbag)	V	V		V																																													
Zafira-B	Body	AHL/AFL (Headlamp Levelling)	V	V	V	V																																													

Vehicle	System 1	System 2	DTC	CURR	ACT	ECUINFOR	Program CAN configuration	Injector Cutoff Test	Adjust idle speed	Adjust idle drive	Idle air control	RPM control	Injector Cutoff	Reset TC signal status	Reset learned values	Program idle speed	Reset Learned Valves	Fuel tank ventilation control	Electronic throttle control	Reset O2 loop block learn map	Learn crank angle sensing error	EGR control	Reset TC signal status	Calibration	Steering angle sensor calibration	Program transponder key	Erase transponder key	Reset Immobilizer	Program Immobilizer output	Reset service interval	Erase remote keys	Program remote key	Reset body control module	Program variant configuration	Read Variant Configuration	Clear Deployment Record	Reset IAC block learn map	Reset ECU	Fuel pump relay test	Program tyre circumference	Bleed clutch hydraulic	Learn gearbox parameters	Touch point adaptation	Additional Touch Point Adaption	Clutch control test	Read security PIN code	BCM link to ECM/Immobilizer	Idle Test	Fuel Correction Test	Service Regeneration
Zafira-B	Body	PAS (Park Pilot)	V	V	V	V																																													
Zafira-B	Body	EHS (Electrical Heater System)	V	V		V																																													
Zafira-B	Body	CIM (Steering Column Module)	V	V		V																																													
Zafira-B	Body	REC (Rear Electrical Centre)	V			V																																													
Zafira-B	Body	UEC (Underhood Electrical Centre)	V	V	V	V																																													
Zafira-B	Body	SLM (Shift Lever Module)	V	V	V	V																																													
Zafira-B	Body	ECC/SAC (Electronic Climate Control)	V	V	V	V																																													
Vivaro	Powertrain	Engine(Diesel)	V	V	V	V									V																																				
Vivaro	Chassis	ABS	V	V		V																																													
Vivaro	Body	Body Control Module	V	V	V	V																																													
Vivaro	Body	Immobiliser	V	V	V	V																																													
Vivaro	Body	Connection Unit	V	V	V	V																																													
Vivaro	Body	Instrument Cluster	V	V	V	V																																													
Vivaro	Body	Airbag	V	V		V																																													

Vehicle	System 1	System 2	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	ECM Immobilizer Learning	Vheicle Variant Coding	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel trim reset	Throttle body relearn	Engine oil life reset	Streering Wheel Angle Reset	Air Bleeding	DPF Regeneration	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor	Replace Diesel particulate filter	Replace recatalyst	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Compression Test	Replace Intake Air Flow Valve	Replace Injector	Return Pump Relay Test	Front Left Solenoid Valve Test	Front Right Solenoid Valve Test	Rear Left Solenoid Valve Test	Rear Right Solenoid Valve Test	Program Type Circumference	Read Configuration
Astra-F	Engine	14 SE																																
Astra-F	Engine	16 LZ 2																																
Astra-F	Engine	16 NZR																																
Astra-F	Engine	18 SE																																
Astra-F	Engine	C 14 NZ																																
Astra-F	Engine	C 14 SE																																
Astra-F	Engine	C 16 SE																																
Astra-F	Engine	C 18 SEL																																
Astra-F	Engine	X 14 NZ																																
Astra-F	Engine	X 14 XE																																
Astra-F	Engine	X 16 NE																																
Astra-F	Engine	X 16 SZR																																
Astra-F	Engine	X 16 XEL																																
Astra-F	Engine	X 18 XE																																
Astra-F	Engine	X 20 XEV																																
Astra-F	Transmission	AF 13/14/20																																
Astra-F	Transmission	AF 13II/20/22/30																																
Astra-F	Body	Immobiliser																																
Astra-F	Body	Airbag-S																																
Astra-G	Engine	C 16 SEL																																
Astra-G	Engine	C 18 NE																																
Astra-G	Engine	C 18 YE																																
Astra-G	Engine	C 20 NE/C 20 SE(8V)																																
Astra-G	Engine	X 12 XE																																
Astra-G	Engine	X 14 XE																																
Astra-G	Engine	X 16 SZR																																
Astra-G	Engine	X 16 XEL																																
Astra-G	Engine	X 17 DTL																																
Astra-G	Engine	X 18 XE1																																
Astra-G	Engine	X 20 DTL																																
Astra-G	Engine	X 20 XER																																
Astra-G	Engine	X 20 XEV																																
Astra-G	Engine	X 24 SE																																
Astra-G	Engine	Y 17 DT																																
Astra-G	Engine	Y 20 DTH																																
Astra-G	Engine	Y 20 DTL																																
Astra-G	Engine	Y 22 DTR																																
Astra-G	Engine	Z 12 XE																																
Astra-G	Engine	Z 14 XE																																
Astra-G	Engine	Z 14 XEP																																
Astra-G	Engine	Z 16 SE																																
Astra-G	Engine	Z 16 XE																																

Vehicle	System 1	System 2	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	ECM Immobilizer Learning	Vheicle Variant Coding	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel trim reset	Throttle body relearn	Engine oil life reset	Streering Wheel Angle Reset	Air Bleeding	DPF Regeneration	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor	Replace Diesel particulate filter	Replace recatalyst	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Compression Test	Replace Intake Air Flow Valve	Replace Injector	Return Pump Relay Test	Front Left Solenoid Valve Test	Front Right Solenoid Valve Test	Rear Left Solenoid Valve Test	Rear Right Solenoid Valve Test	Program Type Circumference	Read Configuration
Astra-G	Engine	Z 16 XEP																																
Astra-G	Engine	Z 16 YNG																																
Astra-G	Engine	Z 17 DTL																																
Astra-G	Engine	Z 18 XE																																
Astra-G	Engine	Z 18 XEL																																
Astra-G	Engine	Z 20 LET																																
Astra-G	Engine	Z 22 SE																																
Astra-G	Transmission	AF 13-II/17/20/22																																
Astra-G	Transmission	AF 13-II/17/20/22 CAN																																
Astra-G	Chassis	ABS-5.3/5.4 (+TC)																																
Astra-G	Chassis	ESP																																
Astra-G	Chassis	Electronic Power Steering																																
Astra-G	Body	Immobiliser																																
Astra-G	Body	Airbag SAB6																																
Astra-G	Body	Airbag																																
Astra-G	Body	Instrument																																
Astra-G	Body	Engine Cooling Module																																
Astra-G	Body	Central Door Lock																																
Astra-G	Body	Add On Heater																																
Astra-G	Body	Softtop Controller																																
Astra-G	Body	Electronic Climate Control																																
Astra-G	Body	Headlamp Levelling Device																																
Astra-G	Infotainment System	Triple Info Display																																
Astra-G	Infotainment System	Multi Info Display																																
Astra-G	Infotainment System	Read security PIN code(Beta)																																
Corsa-B	Engine	C 14 NE																																
Corsa-B	Engine	C 16 NE																																
Corsa-B	Engine	16 NE																																
Corsa-B	Engine	C 14 SE																																
Corsa-B	Engine	Z 14 XE																																
Corsa-B	Engine	Z 14 XEP																																
Corsa-B	Engine	Z 16 SE																																
Corsa-B	Engine	Z 18 XE																																
Corsa-B	Transmission	AF 13/14/20																																
Corsa-B	Transmission	AF 13II/20/22/30																																
Corsa-B	Transmission	AF 13-II/17/20/22 CAN																																
Corsa-B	Chassis	ABS 5.3/5.4 +TC																																
Corsa-B	Chassis	ABS/ESP8																																
Corsa-B	Chassis	Electronic Power Steering																																
Corsa-B	Body	Body Control Module																																
Corsa-B	Body	Immobiliser																																
Corsa-B	Body	Airbag																																

Vehicle	System 1	System 2	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	ECM Immobilizer Learning	Vheicle Variant Coding	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel trim reset	Throttle body relearn	Engine oil life reset	Streering Wheel Angle Reset	Air Bleeding	DPF Regeneration	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor	Replace Diesel particulate filter	Replace recatalyst	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Compression Test	Replace Intake Air Flow Valve	Replace Injector	Return Pump Relay Test	Front Left Solenoid Valve Test	Front Right Solenoid Valve Test	Rear Left Solenoid Valve Test	Rear Right Solenoid Valve Test	Program Type Circumference	Read Configuration
Corsa-B	Body	Instrument																																
Corsa-B	Infotainment System	Triple Info Display																																
Corsa-C	Engine	C 10 NE(E0/E20)																																
Corsa-C	Engine	C 10 YE(E100)																																
Corsa-C	Engine	C 10 YEH(E0 E20)																																
Corsa-C	Engine	C 16 SE																																
Corsa-C	Engine	C 18 XE																																
Corsa-C	Engine	X 18 NXE																																
Corsa-C	Engine	C 14 SE																																
Corsa-C	Engine	C 14 NE																																
Corsa-C	Engine	C 18 NE																																
Corsa-C	Engine	Y 17 DT																																
Corsa-C	Engine	Y 17 DTL																																
Corsa-C	Engine	Y 13 DT																																
Corsa-C	Engine	Z 10 XE																																
Corsa-C	Engine	Z 12 XE																																
Corsa-C	Engine	Z 14 XE																																
Corsa-C	Engine	Z 18 XE																																
Corsa-C	Engine	Z 16 SE																																
Corsa-C	Engine	Z 10 XEP																																
Corsa-C	Engine	Z 13 DT																																
Corsa-C	Engine	Z 14 XEP																																
Corsa-C	Engine	Z 17 DTH																																
Corsa-C	Engine	Z 12 XEP																																
Corsa-C	Engine	Z 16 YNG																																
Corsa-C	Engine	Z 13 DTJ																																
Corsa-C	Transmission	AF 13-II/17/20/22 CAN																																
Corsa-C	Transmission	MTA (Easytronic)																																
Corsa-C	Chassis	ABS-5.3/5.4 (+TC)																																
Corsa-C	Chassis	ABS8/ESP8																																
Corsa-C	Chassis	Electronic Power Steering																																
Corsa-C	Body	Body Control Module																																
Corsa-C	Body	Immobiliser																																
Corsa-C	Body	Airbag																																
Corsa-C	Body	Instrument																																
Corsa-C	Body	Add On Heater																																
Corsa-C	Body	Headlamp Levelling Device																																
Corsa-C	Infotainment System	Triple Info Display																																
Corsa-C	Infotainment System	Read security PIN code(Beta)																																
Omega-B	Engine	20 SE																																
Omega-B	Engine	X 20 SE																																
Omega-B	Engine	X 20 XEV																																

Vehicle	System 1	System 2	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	ECM Immobilizer Learning	Vheicle Variant Coding	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel trim reset	Throttle body relearn	Engine oil life reset	Streering Wheel Angle Reset	Air Bleeding	DPF Regeneration	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor	Replace Diesel particulate filter	Replace recatalyst	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Compression Test	Replace Intake Air Flow Valve	Replace Injector	Return Pump Relay Test	Front Left Solenoid Valve Test	Front Right Solenoid Valve Test	Rear Left Solenoid Valve Test	Rear Right Solenoid Valve Test	Program Type Circumference	Read Configuration
Omega-B	Engine	X 25 DT																																
Omega-B	Engine	X 25 XE																																
Omega-B	Engine	X 30 XE																																
Omega-B	Engine	X 20 DTH																																
Omega-B	Engine	Y 22 XE																																
Omega-B	Engine	Y 22 DTH																																
Omega-B	Engine	Y 26 SE																																
Omega-B	Engine	Y 32 SE																																
Omega-B	Engine	Y 25 DT																																
Omega-B	Engine	Z 22 XE																																
Omega-B	Transmission	AR 25/35																																
Omega-B	Transmission	5L40-E																																
Omega-B	Chassis	ABS-5.3/5.4 (+TC)																																
Omega-B	Chassis	ESP																																
Omega-B	Body	Immobiliser																																
Omega-B	Body	Airbag-S																																
Omega-B	Body	Airbag SAB6																																
Omega-B	Body	Airbag																																
Omega-B	Body	Add On Heater																																
Omega-B	Body	Headlamp Levelling Device																																
Omega-B	Infotainment System	Triple Info Display																																
Omega-B	Infotainment System	Multi Info Display																																
Tigra-B	Engine	Z 13 DT																																
Tigra-B	Engine	C 14 SE																																
Tigra-B	Engine	Z 14 XE																																
Tigra-B	Engine	Z 14 XEP																																
Tigra-B	Engine	Z 16 SE																																
Tigra-B	Engine	Z 18 XE																																
Tigra-B	Transmission	MTA (Easytronic)																																
Tigra-B	Transmission	AF 13/14/20																																
Tigra-B	Transmission	AF 13II/20/22/30																																
Tigra-B	Transmission	AF 13-II/17/20/22 CAN																																
Tigra-B	Chassis	ABS8/ESP8																																
Tigra-B	Chassis	ABS 5.3/5.4 +TC																																
Tigra-B	Chassis	Electronic Power Steering																																
Tigra-B	Body	Body Control Module																																
Tigra-B	Body	Immobiliser																																
Tigra-B	Body	Airbag																																
Tigra-B	Body	Instrument																																
Tigra-B	Body	Electrohydraulic Hardtop																																

Vehicle	System 1	System 2	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	ECM Immobilizer Learning	Vheicle Variant Coding	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel trim reset	Throttle body relearn	Engine oil life reset	Streering Wheel Angle Reset	Air Bleeding	DPF Regeneration	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor	Replace Diesel particulate filter	Replace recatalyst	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Compression Test	Replace Intake Air Flow Valve	Replace Injector	Return Pump Relay Test	Front Left Solenoid Valve Test	Front Right Solenoid Valve Test	Rear Left Solenoid Valve Test	Rear Right Solenoid Valve Test	Program Type Circumference	Read Configuration
Tigra-B	Infotainment System	Read security PIN code(Beta)																																
Vectra-B	Engine	16 LZ 2																																
Vectra-B	Engine	20 NEJ																																
Vectra-B	Engine	C 20 SEL																																
Vectra-B	Engine	C 22 SEL																																
Vectra-B	Engine	X 16 SZR																																
Vectra-B	Engine	X 16 XEL																																
Vectra-B	Engine	X 18 XE																																
Vectra-B	Engine	X 18 XE1																																
Vectra-B	Engine	X 20 DTL																																
Vectra-B	Engine	X 20 XEV																																
Vectra-B	Engine	X 25 XE																																
Vectra-B	Engine	X 20 DTH																																
Vectra-B	Engine	Y 16 XE																																
Vectra-B	Engine	Y 20 DTH																																
Vectra-B	Engine	Y 22 DTR																																
Vectra-B	Engine	Y 26 SE																																
Vectra-B	Engine	Z 16 XE																																
Vectra-B	Engine	Z 18 XE																																
Vectra-B	Engine	Z 18 XEL																																
Vectra-B	Engine	Z 22 SE																																
Vectra-B	Transmission	AF 13II/20/22/30																																
Vectra-B	Transmission	AF 13-II/17/20/22																																
Vectra-B	Transmission	AF 13-II/17/20/22 CAN																																
Vectra-B	Chassis	ABS 430																																
Vectra-B	Chassis	ABS-5.3/5.4 (+TC)																																
Vectra-B	Body	Immobiliser																																
Vectra-B	Body	Airbag																																
Vectra-B	Body	Airbag SAB6																																
Vectra-B	Body	Instrument																																
Vectra-B	Body	Add On Heater																																
Vectra-B	Body	Central Door Lock																																
Vectra-B	Body	Headlamp Levelling Device(Left)																																
Vectra-B	Body	Headlamp Levelling Device(Right)																																
Vectra-B	Infotainment System	Triple Info Display																																
Vectra-B	Infotainment System	Read security PIN code(Beta)																																
Zafira	Engine	X 16 XEL																																
Zafira	Engine	X 18 XE1																																
Zafira	Engine	C 20 SEL																																
Zafira	Engine	X 20 DTL																																
Zafira	Engine	Y 20 DTH																																
Zafira	Engine	Y 22 DTR																																

Vehicle	System 1	System 2	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	ECM Immobilizer Learning	Vheicle Variant Coding	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel trim reset	Throttle body relearn	Engine oil life reset	Streering Wheel Angle Reset	Air Bleeding	DPF Regeneration	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor	Replace Diesel particulate filter	Replace recatalyst	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Compression Test	Replace Intake Air Flow Valve	Replace Injector	Return Pump Relay Test	Front Left Solenoid Valve Test	Front Right Solenoid Valve Test	Rear Left Solenoid Valve Test	Rear Right Solenoid Valve Test	Program Type Circumference	Read Configuration
Zafira	Engine	Z 16 XE																																
Zafira	Engine	Z 16 YNG																																
Zafira	Engine	Z 18 XE																																
Zafira	Engine	Z 22 SE																																
Zafira	Engine	C 20 SE																																
Zafira	Engine	Z 20 LET																																
Zafira	Transmission	AF 13-II/17/20/22																																
Zafira	Transmission	AF 13-II/17/20/22 CAN																																
Zafira	Chassis	ABS-5.3/5.4 (+TC)																																
Zafira	Chassis	ESP																																
Zafira	Chassis	Electronic Power Steering																																
Zafira	Body	Airbag SAB6																																
Zafira	Body	Airbag																																
Zafira	Body	Instrument																																
Zafira	Body	Engine Cooling Module																																
Zafira	Body	Central Door Lock																																
Zafira	Body	Headlamp Levelling Device(Left)																																
Zafira	Body	Headlamp Levelling Device(Right)																																
Zafira	Infotainment System	Triple Info Display																																
Zafira	Infotainment System	Read security PIN code(Beta)																																
Meriva	Engine	Y 13 DT																																
Meriva	Engine	Z 13 DTJ																																
Meriva	Engine	Z 14 XEP																																
Meriva	Engine	Z 16 LET																																
Meriva	Engine	Z 16 SE																																
Meriva	Engine	Z 16 XE																																
Meriva	Engine	Z 16 XEP																																
Meriva	Engine	Y 17 DT																																
Meriva	Engine	Z 17 DT																																
Meriva	Engine	Z 17 DTH																																
Meriva	Engine	Z 17 DTR																																
Meriva	Engine	Z 18 XE																																
Meriva	Transmission	MTA (Easytronic)																																
Meriva	Chassis	ABS																																
Meriva	Chassis	Electronic Power Steering																																
Meriva	Body	Body Control Module																																
Meriva	Infotainment System	Read security PIN code(Beta)																																
Captiva/Antara Long Body	Powertrain	ECM(DIESEL)	V	V	V	V	V	V																										
Captiva/Antara Long Body	Powertrain	ECM(2.4D)							V	V																								
Captiva/Antara Long Body	Powertrain	ECM(3.2D)									V	V	V																					
Captiva/Antara Long Body	Powertrain	TCM																																
Captiva/Antara Long Body	Chassis	Electronic Brake Control Module												V	V																			

Vehicle	System 1	System 2	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	ECM Immobilizer Learning	Vheicle Variant Coding	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel trim reset	Throttle body relearn	Engine oil life reset	Streering Wheel Angle Reset	Air Bleeding	DPF Regeneration	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor	Replace Diesel particulate filter	Replace recatalyst	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Compression Test	Replace Intake Air Flow Valve	Replace Injector	Return Pump Relay Test	Front Left Solenoid Valve Test	Front Right Solenoid Valve Test	Rear Left Solenoid Valve Test	Rear Right Solenoid Valve Test	Program Type Circumference	Read Configuration
Captiva/Antara Long Body	Chassis	Transfer Case Control Module																																
Captiva/Antara Long Body	Body	SDM(SRSAirbag)																																
Captiva/Antara Long Body	Body	Instrument Panel Cluster																																
Captiva/Antara Long Body	Body	Body Control Module																																
Captiva/Antara Long Body	Body	Theft Deterrent Module																																
Captiva/Antara Long Body	Body	Remote Function Actuator																																
Captiva/Antara Short Body	Engine	2.0 L (Diesel)																																
Captiva/Antara Short Body	Engine	Z 24 XE																																
Captiva/Antara Short Body	Engine	Z 32 SE																																
Captiva/Antara Short Body	Transmission	Automatic Transmission																																
Captiva/Antara Short Body	Transmission	TCCM (Transfer Case Control Module)																																
Captiva/Antara Short Body	Chassis	ABS/TC/ESP (Vehicle Dynamic System)																																
Captiva/Antara Short Body	Body	Immobiliser																																
Captiva/Antara Short Body	Body	IPC (Instrument)																																
Captiva/Antara Short Body	Body	Central Door Lock																																
Captiva/Antara Short Body	Body	Anti Theft Warning System																																
Captiva/Antara Short Body	Body	Wipers/Washer																																
Captiva/Antara Short Body	Body	Interior Lighting																																
Captiva/Antara Short Body	Body	Exterior Lighting/Turn Indicator System																																
Captiva/Antara Short Body	Body	SDM (Airbag)																																
Captiva/Antara Short Body	Body	ECC (Electronic Climate Control)																																
Captiva/Antara Short Body	Body	PAS (Park Pilot)																																
Captiva/Antara Short Body	Body	BCM (Body Control Module)																																
Captiva/Antara Short Body	Body	RFA (Multipurpose Receiver Module)																																
Captiva/Antara Short Body	Body	HVAC (Heating Ventilation and Cooling)																																
Captiva/Antara Short Body	Body	SLM (Shift Lever Module)																																
Captiva/Antara Short Body	Body	XBCM (Auxiliary Body Control Module)																																
Astra-H	Engine	A 16 LET																																
Astra-H	Engine	A 16 XER																																
Astra-H	Engine	A 17 DTJ																																
Astra-H	Engine	A 17 DTR																																
Astra-H	Engine	A 18 XER																																
Astra-H	Engine	Y 13 DTH																																
Astra-H	Engine	Z 14 XEP																																
Astra-H	Engine	Z 16 XEP																																
Astra-H	Engine	Z 17 DTH																																
Astra-H	Engine	Z 17 DTL																																
Astra-H	Engine	Z 18 XE																																
Astra-H	Engine	Z 20 LEL																																
Astra-H	Engine	Z 20 LER																																
Astra-H	Engine	Z 13 DTH																																
Astra-H	Engine	Z 19 DTH																																

Vehicle	System 1	System 2	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	ECM Immobilizer Learning	Vheicle Variant Coding	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel trim reset	Throttle body relearn	Engine oil life reset	Streering Wheel Angle Reset	Air Bleeding	DPF Regeneration	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor	Replace Diesel particulate filter	Replace recatalyst	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Compression Test	Replace Intake Air Flow Valve	Replace Injector	Return Pump Relay Test	Front Left Solenoid Valve Test	Front Right Solenoid Valve Test	Rear Left Solenoid Valve Test	Rear Right Solenoid Valve Test	Program Type Circumference	Read Configuration
Astra-H	Engine	Z 20 LEH																																
Astra-H	Engine	Z 12 XEP																																
Astra-H	Engine	Z 14 XEL																																
Astra-H	Engine	Z 18 XER																																
Astra-H	Engine	Z 19 DT														V	V	V	V	V	V													
Astra-H	Engine	Z 16 LET																																
Astra-H	Engine	Z 16 XE1																																
Astra-H	Engine	Z 16 XER																																
Astra-H	Engine	Z 17 DTJ																																
Astra-H	Engine	Z 17 DTR																																
Astra-H	Engine	Z 22 YH																																
Astra-H	Transmission	AF 17-4																																
Astra-H	Transmission	MTA (Easytronic)																																
Astra-H	Transmission	AF 40-6																				V												
Astra-H	Transmission	MTA (Easytronic Magneti Marelli)																																
Astra-H	Transmission	AF 22-4																																
Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)																					V	V										
Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)																																
Astra-H	Chassis	ABS/TC/ESP ECU (Electronic Control Unit)																																
Astra-H	Chassis	TPMS ECU (Tyre Pressure Monitoring)																																
Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)																																
Astra-H	Chassis	CDC (Continuous Damping Control)																																
Astra-H	Body	Instrument																																
Astra-H	Body	Exterior Lighting/Turn Indicator System																																
Astra-H	Body	IPC ECU (Instrument Control Unit)																																
Astra-H	Body	SDM (Airbag)																																
Astra-H	Body	AHL/AFL (Headlamp Levelling)																																
Astra-H	Body	PAS (Park Pilot)																																
Astra-H	Body	EHS (Electrical Heater System)																																
Astra-H	Body	CIM (Steering Column Module)																																
Astra-H	Body	REC (Rear Electrical Centre)																																
Astra-H	Body	UEC (Underhood Electrical Centre)																																
Astra-H	Body	PEPS (Open/Start)																																
Astra-H	Body	Electrohydraulic Hardtop																																
Astra-H	Body	ECC/SAC (Electronic Climate Control)																																
Astra-H	Body	SLM (Shift Lever Module)																																
Corsa-D	Engine	A 10 XEP																																
Corsa-D	Engine	A 12 XEL																																
Corsa-D	Engine	A 12 XER																																
Corsa-D	Engine	A 13 DTR																																
Corsa-D	Engine	A 13 DTC																																
Corsa-D	Engine	A 13 DTE																																

Vehicle	System 1	System 2	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	ECM Immobilizer Learning	Vheicle Variant Coding	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel trim reset	Throttle body relearn	Engine oil life reset	Streering Wheel Angle Reset	Air Bleeding	DPF Regeneration	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor	Replace Diesel particulate filter	Replace recatalyst	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Compression Test	Replace Intake Air Flow Valve	Replace Injector	Return Pump Relay Test	Front Left Solenoid Valve Test	Front Right Solenoid Valve Test	Rear Left Solenoid Valve Test	Rear Right Solenoid Valve Test	Program Type Circumference	Read Configuration
Corsa-D	Engine	A 14 XEL																																
Corsa-D	Engine	A 14 XER																																
Corsa-D	Engine	A 16 LEL																																
Corsa-D	Engine	A 16 LER																																
Corsa-D	Engine	A 17 DTS																																
Corsa-D	Engine	Z 10 XEP																																
Corsa-D	Engine	Z 12 XEP																																
Corsa-D	Engine	Z 13 DTE																																
Corsa-D	Engine	Z 13 DTH																																
Corsa-D	Engine	Z 13 DTJ																																
Corsa-D	Engine	Z 14 XEP																																
Corsa-D	Engine	Z 16 LER																																
Corsa-D	Engine	Z 17 DTR																																
Corsa-D	Engine	Z 16 LEL																																
Corsa-D	Transmission	AF 13-4																																
Corsa-D	Transmission	MTA (Easytronic)																																
Corsa-D	Transmission	MTA (Easytronic Magneti Marelli)																																
Corsa-D	Chassis	ABS/ESP																																
Corsa-D	Chassis	Electronic Power Steering																																
Corsa-D	Body	AFL (Adaptive Forward Lighting)																																
Corsa-D	Body	TIM (Trailer Interface Module)																																
Corsa-D	Body	Immobiliser																																
Corsa-D	Body	IPC (Instrument)																																
Corsa-D	Body	Central Door Lock																																
Corsa-D	Body	Anti Theft Warning System																																
Corsa-D	Body	Heating Ventilation and Air Cond.																																
Corsa-D	Body	Wipers/Washer																																
Corsa-D	Body	Interior Lighting																																
Corsa-D	Body	Exterior Lighting																																
Corsa-D	Body	SDM (Airbag)																																
Corsa-D	Body	PAS (Park Pilot)																																
Corsa-D	Body	EHS (Electrical Heater System)																																
Corsa-D	Body	BCM (Body Control Module)																																
Corsa-D	Body	Stop/Start System																																
Vectra-C	Engine	Engine Cooling																																
Vectra-C	Engine	Y 20 DTH																																
Vectra-C	Engine	Y 22 DTR																																
Vectra-C	Engine	Y 30 DT																																
Vectra-C	Engine	Z 16 XE																																
Vectra-C	Engine	Z 16 XEP																																
Vectra-C	Engine	Z 18 XE																																
Vectra-C	Engine	Z 18 XER																																

Vehicle	System 1	System 2	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	ECM Immobilizer Learning	Vheicle Variant Coding	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel trim reset	Throttle body relearn	Engine oil life reset	Streering Wheel Angle Reset	Air Bleeding	DPF Regeneration	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor	Replace Diesel particulate filter	Replace recatalyst	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Compression Test	Replace Intake Air Flow Valve	Replace Injector	Return Pump Relay Test	Front Left Solenoid Valve Test	Front Right Solenoid Valve Test	Rear Left Solenoid Valve Test	Rear Right Solenoid Valve Test	Program Type Circumference	Read Configuration
Vectra-C	Engine	Z 19 DT																																
Vectra-C	Engine	Z 19 DTH																																
Vectra-C	Engine	Z 20 NET																																
Vectra-C	Engine	Z 22 SE																																
Vectra-C	Engine	Z 22 YH																																
Vectra-C	Engine	Z 28 NEH																																
Vectra-C	Engine	Z 28 NEL																																
Vectra-C	Engine	Z 28 NET																																
Vectra-C	Engine	Z 30 DT																																
Vectra-C	Engine	Z 32 SE																																
Vectra-C	Transmission	AF 23-5/33-5/40-6																																
Vectra-C	Transmission	MTA (Easytronic)																																
Vectra-C	Transmission	CVTronic																																
Vectra-C	Transmission	AF 23-5/33-5																																
Vectra-C	Chassis	ABS/TC/ESP																																
Vectra-C	Chassis	TPMS (Tyre Pressure Monitoring System)																																
Vectra-C	Chassis	Electronic Cruise Control																																
Vectra-C	Chassis	EHPS (Electrohydraulic Power Steering)																																
Vectra-C	Chassis	CDC (Continuous Damping Control)																																
Vectra-C	Body	Immobiliser																																
Vectra-C	Body	IPC(Instrument)																																
Vectra-C	Body	Central Door Lock																																
Vectra-C	Body	Anti Theft Warning System																																
Vectra-C	Body	Heating Ventilation and Air Cond.																																
Vectra-C	Body	Additional Heating																																
Vectra-C	Body	Electronic Seat Memory/Seat Heating																																
Vectra-C	Body	Wipers/Washer																																
Vectra-C	Body	Turn Indication																																
Vectra-C	Body	Interior Lighting																																
Vectra-C	Body	Exterior Lighting																																
Vectra-C	Body	Power Window Lifter																																
Vectra-C	Body	Electric Adjustable Mirrors																																
Vectra-C	Body	SDM (Airbag; Sensing/Diagnostic Module)																																
Vectra-C	Body	SRM (Sun Roof Module)																																
Vectra-C	Body	ECC (Electronic Climate Control)																																
Vectra-C	Body	SAC (Automatic Climate Control)																																
Vectra-C	Body	AHL/AFL (Headlamp Levelling)																																
Vectra-C	Body	Electrical Horn																																
Vectra-C	Body	PAS (Park Pilot)																																
Vectra-C	Body	EHS (Electrical Heater System)																																
Vectra-C	Body	CIM (Steering Column Module)																																
Vectra-C	Body	BCM (Body Control Module)																																

Vehicle	System 1	System 2	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	ECM Immobilizer Learning	Vheicle Variant Coding	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel trim reset	Throttle body relearn	Engine oil life reset	Streering Wheel Angle Reset	Air Bleeding	DPF Regeneration	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor	Replace Diesel particulate filter	Replace recatalyst	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Compression Test	Replace Intake Air Flow Valve	Replace Injector	Return Pump Relay Test	Front Left Solenoid Valve Test	Front Right Solenoid Valve Test	Rear Left Solenoid Valve Test	Rear Right Solenoid Valve Test	Program Type Circumference	Read Configuration
Vectra-C	Body	REC (Rear Electrical Centre)																																
Vectra-C	Body	UEC (Underhood Electrical Centre)																																
Vectra-C	Body	DDM (Driver Door Module)																																
Vectra-C	Body	PDM (Passenger Door Module)																																
Vectra-C	Body	SLM (Shift Lever Module)																																
Zafira-B	Engine	Z 16 XEP																																
Zafira-B	Engine	Z 18 XER																																
Zafira-B	Engine	Z 19 DT																																
Zafira-B	Engine	Z 19 DTH																																
Zafira-B	Engine	Z 20 LER																																
Zafira-B	Engine	Z 22 YH																																
Zafira-B	Engine	Z 16 YNG																																
Zafira-B	Engine	Z 20 LEH																																
Zafira-B	Engine	Z 16 XE1																																
Zafira-B	Engine	Z 16 XER																																
Zafira-B	Engine	Z 16 XNT																																
Zafira-B	Engine	Z 17 DTJ																																
Zafira-B	Engine	A 16 XER																																
Zafira-B	Engine	A 16 XNT																																
Zafira-B	Engine	A 17 DTJ																																
Zafira-B	Engine	A 17 DTR																																
Zafira-B	Engine	A 18 XER																																
Zafira-B	Transmission	AF 40-6																																
Zafira-B	Transmission	AF 22-4																																
Zafira-B	Transmission	MTA (Easytronic)																																
Zafira-B	Chassis	ABS/TC/ESP (Vehicle Dynamic System)																																
Zafira-B	Chassis	TPMS (Tyre Pressure Monitoring System)																																
Zafira-B	Chassis	ABS/TC/ESP ECU (Electronic Control Unit)																																
Zafira-B	Chassis	TPMS ECU (Tyre Pressure Monitoring)																																
Zafira-B	Chassis	EHPS (Electrohydraulic Power Steering)																																
Zafira-B	Chassis	CDC (Continuous Damping Control)																																
Zafira-B	Body	PEPS (Open/Start)																																
Zafira-B	Body	Immobiliser																																
Zafira-B	Body	Instrument																																
Zafira-B	Body	Central Door Lock																																
Zafira-B	Body	Anti Theft Warning System																																
Zafira-B	Body	Wipers/Washer																																
Zafira-B	Body	Interior Lighting																																
Zafira-B	Body	Exterior Lighting/Turn Indicator System																																
Zafira-B	Body	IPC ECU (Instrument Control Unit)																																
Zafira-B	Body	SDM (Airbag)																																
Zafira-B	Body	AHL/AFL (Headlamp Levelling)																																

Vehicle	System 1	System 2	Cranking Test	Wheel Circumference	Injector IQA Coding	ECM Replace	ECM Immobilizer Learning	Vheicle Variant Coding	Subnet Configuration List - High Speed	Circumference of the wheel	Fuel trim reset	Throttle body relearn	Engine oil life reset	Streering Wheel Angle Reset	Air Bleeding	DPF Regeneration	Replace Mass air flow sensor	Replace Rail pressure sensor	Replace Differential pressure sensor	Replace Diesel particulate filter	Replace recatalyst	Learn selector lever N position	Sensor cluster calibration	Reset deflation dected system	Compression Test	Replace Intake Air Flow Valve	Replace Injector	Return Pump Relay Test	Front Left Solenoid Valve Test	Front Right Solenoid Valve Test	Rear Left Solenoid Valve Test	Rear Right Solenoid Valve Test	Program Type Circumference	Read Configuration
Zafira-B	Body	PAS (Park Pilot)																																
Zafira-B	Body	EHS (Electrical Heater System)																																
Zafira-B	Body	CIM (Steering Column Module)																																
Zafira-B	Body	REC (Rear Electrical Centre)																																
Zafira-B	Body	UEC (Underhood Electrical Centre)																																
Zafira-B	Body	SLM (Shift Lever Module)																																
Zafira-B	Body	ECC/SAC (Electronic Climate Control)																																
Vivaro	Powertrain	Engine(Diesel)																							V	V	V							
Vivaro	Chassis	ABS																										V	V	V	V	V	V	
Vivaro	Body	Body Control Module																																
Vivaro	Body	Immobiliser																																
Vivaro	Body	Connection Unit																																V
Vivaro	Body	Instrument Cluster																																
Vivaro	Body	Airbag																																

Vehicle	TYPE1	TYPE2	YEAR	SYSTEM	DTC Analysis	DTC Mode	FREEZE FRAME	Data Analysis	Actuation Test	ECU INFORMATIN	T_ONOFF	Secondary Repair Air Bleeding	A.T.Learning Value Clear	Reset Memory	Initializtion of immobilizer
Alza	3SZ-VE	M502	Nov 09-	System Searching											
Alza	3SZ-VE	M502	Nov 09-	EFI	V		V	V	V	V	V			V	
Alza	3SZ-VE	M502	Nov 09-	A/T	V		V	V	V	V				V	
Alza	3SZ-VE	M502	Nov 09-	ABS	V	V	V	V	V			V			
Alza	3SZ-VE	M502	Nov 09-	SRS-AIRBAG	V										
Alza	3SZ-VE	M502	Nov 09-	IMB	V			V		V					V
Kancil	ED-DE	L201	Jun 04-	EFI	V		V	V	V		V				
Kelisa	ED-DE	L703	Oct 03-	EFI	V		V	V	V		V				
Kelisa	EJ-DE	L701	Oct 03-	EFI	V		V	V	V	V	V				
Kelisa	EJ-DE	L701	Aug 01-Oct 03	System Searching											
Kelisa	EJ-DE	L701	Aug 01-Oct 03	EFI	V		V	V	V		V			V	
Kelisa	EJ-DE	L701	Aug 01-Oct 03	IMB	V			V		V					V
Kelisa	EJ-DE	L701	Aug 01-Oct 03	IMB	V										V
Kelisa	EJ-VE	L701	Dec 01-	System Searching											
Kelisa	EJ-VE	L701	Dec 01-	EFI	V		V	V	V	V	V			V	
Kelisa	EJ-VE	L701	Dec 01-	SRS-AIRBAG	V										
Kelisa	EJ-VE	L701	Dec 01-	IMB	V			V		V					V
Kembara	HC-E	J100	Aug 98-MAY 03	EFI	V		V	V	V		V				
Kembara	K3-VE	J102	May 03-	System Searching											
Kembara	K3-VE	J102	May 03-	EFI	V		V	V	V	V	V				
Kembara	K3-VE	J102	May 03-	AT	V		V	V	V				V		
Kembara	K3-VE	J102	May 03-	ABS	V	V	V	V	V			V			
Kembara	K3-VE	J102	May 03-	SRS-AIRBAG	V										
Kenari	EJ-DE	L901	Jun 04-	EFI	V		V	V	V	V	V				
Kenari	EJ-DE	L901	Jun 00-Jun 04	System Searching											
Kenari	EJ-DE	L901	Jun 00-Jun 04	EFI	V		V	V	V		V			V	
Kenari	EJ-DE	L901	Jun 00-Jun 04	IMB	V			V		V					V
Kenari	EJ-DE	L901	Jun 00-Jun 04	IMB	V										V
Kenari	EJ-VE	L901	Oct 00-	System Searching											
Kenari	EJ-VE	L901	Oct 00-	EFI	V		V	V	V		V			V	
Kenari	EJ-VE	L901	Oct 00-	EFI	V		V	V	V	V	V			V	
Kenari	EJ-VE	L901	Oct 00-	SRS-AIRBAG	V										
Kenari	EJ-VE	L901	Oct 00-	IMB	V			V		V					V
Kenari	EJ-VE	L901	Oct 00-	IMB	V										V
MYVI	EJ-VE	M302	May 05-	System Searching											
MYVI	EJ-VE	M302	May 05-	EFI	V		V	V	V	V	V			V	
MYVI	EJ-VE	M302	May 05-	ABS	V	V	V	V	V			V			
MYVI	EJ-VE	M302	May 05-	SRS-AIRBAG	V										
MYVI	EJ-VE	M302	May 05-	IMB	V			V		V					V
MYVI	K3-VE	M301	May 05-	System Searching											
MYVI	K3-VE	M301	May 05-	EFI	V		V	V	V	V	V			V	
MYVI	K3-VE	M301	May 05-	AT	V		V	V	V				V		
MYVI	K3-VE	M301	May 05-	ABS	V	V	V	V	V			V			
MYVI	K3-VE	M301	May 05-	SRS-AIRBAG	V										
MYVI	K3-VE	M301	May 05-	IMB	V			V		V					V
VIVA	ED-VE	L252	April 07-	System Searching											
VIVA	ED-VE	L252	April 07-	EFI	V		V	V	V	V	V				
VIVA	ED-VE	L252	April 07-	ABS	V	V	V	V	V			V			
VIVA	EF-VE	L250	April 07-	System Searching											
VIVA	EF-VE	L250	April 07-	EFI	V		V	V	V	V	V				
VIVA	EF-VE	L250	April 07-	ABS	V	V	V	V	V			V			
VIVA	EJ-VE	L251	April 07	System Searching											
VIVA	EJ-VE	L251	April 07	EFI	V		V	V	V	V	V				
VIVA	EJ-VE	L251	April 07	ABS	V	V	V	V	V			V			
VIVA	EJ-VE	L251	April 07	SRS-AIRBAG	V										

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
107	Engine ECU	Petrol engine	ME795	V	V	V		V																																	
107	Gearbox ECU	MMT		V	V	V			V	V																															
107	Airbag	Airbag		V	V																																				
107	ABS or ESP	ABS or ESP		V	V	V					V																														
107	Coded anti-start	ADC		V	V	V						V	V																												
107	Power steering	DAE		V	V									V	V																										
206	Built-In system interface	Built-In system interface		V	V	V	V									V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V								
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	7LZ MM5NP	V	V	V	V																											V							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P	V	V	V	V																											V							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	HFX J34P	V	V	V	V																											V	V	V					
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000	V	V	V	V																											V			V				
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000	V	V	V	V																											V			V				
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D J34P	V	V	V	V																											V	V	V					
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFX BOSCH MP7.3	V	V	V	V																															V			
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFX MM1AP	V	V	V	V																																V		
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LP	V	V	V	V																																		
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME7.4.4	V	V	V	V																											V			V				
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME7.4.4 FLEX FUEL	V	V	V	V																											V			V				
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000	V	V	V	V																											V			V				
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000	V	V	V	V																											V			V				
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P	V	V	V	V																											V	V	V					
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW ME749	V	V	V	V																											V							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW ME749 BIOFLEX	V	V	V	V																											V							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4	V	V	V	V																											V			V				
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4 FLEX FUEL	V	V	V	V																											V			V				
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5	V	V	V	V																											V			V				
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4	V	V	V	V																											V			V				
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4 FLEX FUEL	V	V	V	V																											V			V				
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5	V	V	V	V																											V			V				
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU or N6A or N6B ME749 BIO FLEX	V	V	V	V																											V							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU J35	V	V	V	V																											V							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFK MM6LP	V	V	V	V																																		
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP	V	V	V	V																																		
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM4.8P	V	V	V	V																											V							
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HX/8HZ BOSCH EDC16C3 EURO3	V	V	V	V																																		
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4	V	V	V	V																																		
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4	V	V	V	V																																		
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3	V	V	V	V																																		
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3	V	V	V	V																																		V
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3	V	V	V	V																																		

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2	V	V	V	V																																			
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2	V	V	V	V																																			
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3	V	V	V	V																																			
206	Engines automatic gearbox	Diesel fuel additive control unit		V	V	V	V																																			
206	Engines automatic gearbox	AL4 automatic gearbox		V	V	V	V																																			
206	Engines automatic gearbox	AL4 automatic gearbox		V	V	V	V																																			
206	Alarm	Alarm		V		V	V																																			
206	Driver informationCommunication	Display/Telematics (AMF)		V																																						
206	Driver informationCommunication	Display/Telematics (RT3)		V	V	V	V																																			
206	Driver informationCommunication	Radio		V	V	V	V											V																								
206	Driver informationCommunication	CD Player		V	V	V	V																																			
206	Driver informationCommunication	Instrument panel		V	V	V	V																																			
206	Driver informationCommunication	Switching module steering wheel		V	V		V																																			
206	Driver informationCommunication	On-board navigation system		V	V		V																																			
206	VisibilityLighting	Driving school			V	V	V																																			
206	VisibilityLighting	Rain/sunlight sensor		V			V																																			
206	Airbag	Airbag SAC Central		V	V		V																																			
206	Control the openings	Electric retractable roof		V	V	V	V																																			
206	Heatingventilation	A/C		V	V	V	V																																			
206	Active safety	ABS TEVES MK20		V	V	V	V																																			
206	Active safety	ABS MK70		V	V	V	V																															V				
206	Active safety	ESP MK60		V	V	V	V																																			
206	Electric pump unit (power steering)	Power steering		V	V		V																																			
207	Driving assistance Comfort	Parking aid		V	V	V	V																															V				
207	Driving assistance Comfort	Heating/ventilation		V	V	V	V																															V				
207	Driving assistance Comfort	Under inflation detection		V	V		V																																			
207	Driving assistance Comfort	Power steering		V	V		V																																			
207	Built-In system interface	Built-In system interface		V																																						
207	Inform the driver Audio Communication	Multifunction display		V	V	V	V																																			
207	Inform the driver Audio Communication	Radio		V	V	V	V																																			
207	Inform the driver Audio Communication	CD player		V		V	V																																			
207	Inform the driver Audio Communication	Instrument panel		V	V	V	V																															V				
207	Inform the driver Audio Communication	Switch module at the steering wheel		V	V	V	V																																			
207	Inform the driver Audio Communication	Warning light showing seat belt not fastened				V	V																																			
207	Inform the driver Audio Communication	Battery charge status unit		V	V		V																															V				
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5	V	V	V	V																												V							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6B BOSCH ME7.4.5	V	V	V	V																												V							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5	V	V	V	V																												V							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FX MED 17.4	V	V	V	V																																			
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FY MED 17.4	V	V	V	V																																			

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LPC	V	V	V	V																																			
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4	V	V	V	V																																			
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4	V	V	V	V																																			
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV17.4	V	V	V	V																																			
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FR MEV17.4	V	V	V	V																																			
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FR MED17.4	V	V	V	V																																			
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4	V	V	V	V																																			
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3	V	V	V	V																																			
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4	V	V	V	V																																			
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3	V	V	V	V																																			
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C3	V	V	V	V																																			
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3	V	V	V	V																																			
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3	V	V	V	V																																			
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HL HDI SID807	V	V	V	V																																			
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HR HDI SID807	V	V	V	V																																			
207	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox	V	V	V	V																																			
207	Engine Gearbox	Gearbox ECU	Controlled manual gearbox (BVMP_MA)	V	V	V	V																																			
207	Engine Gearbox	Gearbox ECU	CFC300P	V	V	V	V																																			
207	Vehicle protection Management of accesses	Folding roof		V	V	V	V																																			
207	Active and passive safety	ABS or ESP ECU		V	V	V	V																																			
207	Active and passive safety	Airbag ECU		V	V		V																															V				
207	Visibility Lighting Signalling	Rain/sunlight sensor		V			V																																			
207	Visibility Lighting Signalling	Static AFS		V	V	V	V																																			
207	Visibility Lighting Signalling	Switch module at the steering wheel		V	V	V	V																																			
208	Driving assistance Comfort	Electric power steering		V	V		V																																			
208	Built-In system interface	Built-In system interface		V			V																																			
208	Inform the driver Audio Communication	Multiplexed control panel		V	V	V	V																																			
208	Inform the driver Audio Communication	External CD player		V	V	V	V																																			
208	Inform the driver Audio Communication	Air conditioning		V	V	V	V																																			
208	Inform the driver Audio Communication	Instrument panel		V	V	V	V																																			
208	Inform the driver Audio Communication	Switch module at the steering wheel		V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HP DV6DTED 92 CV	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HP DV6DTED 92 CV	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME749_EC5	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3	V	V	V	V																																			

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHL DCM 3.4	V	V	V	V																																			
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHF DCM 3.4	V	V	V	V																																			
208	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox	V	V	V	V																																			
208	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox	V	V	V	V																																			
208	Engine Gearbox	Gearbox ECU	CFC300P gearbox	V	V	V	V																																			
208	Engine Gearbox	Gearbox ECU	BVA_AL4	V	V	V	V																																			
208	Active and passive safety	ABS or ESP ECU		V	V	V	V																																			
208	Active and passive safety	Airbag ECU		V	V		V																																			
301	Driving assistance Comfort	Power steering		V	V	V	V																																			
301	Driving assistance Comfort	Parking aid		V	V	V	V																															V				
301	Built-In system interface	Built-In system interface		V			V																																			
301	Inform the driver Audio Communication	Multifunction display		V	V	V	V																																			
301	Inform the driver Audio Communication	Radio		V	V	V	V																																			
301	Inform the driver Audio Communication	Instrument panel		V	V	V	V																																			
301	Inform the driver Audio Communication	Switch module at the steering wheel		V	V	V	V																																			
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4	V	V	V	V																																			
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4	V	V	V	V																																			
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO	V	V	V	V																																			
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5	V	V	V	V																																			
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21	V	V	V	V																																			
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3	V	V	V	V																																			
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3	V	V	V	V																																			
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3	V	V	V	V																																			
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3	V	V	V	V																																			
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4	V	V	V	V																																			
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHL DCM 3.4	V	V	V	V																																			
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHF DCM 3.4	V	V	V	V																																			
301	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox	V	V	V	V																																			
301	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox	V	V	V	V																																			
301	Engine Gearbox	Gearbox ECU	CFC300P gearbox	V	V	V	V																																			
301	Engine Gearbox	Gearbox ECU	BVA_AT8	V	V	V	V																																			
301	Vehicle protection Management of accesses	Driver's door module		V	V	V	V																																			
301	Active and passive safety	ABS or ESP ECU		V	V	V	V																																			
301	Active and passive safety	Airbag ECU		V	V		V																																			
307	Built-in systems interface	Built-in systems interface		V	V	V	V															V																				
307	Alarm	Alarm		V		V	V																																			

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
307	Driver informationCommunication	Multifunction display		V																																						
307	Driver informationCommunication	Parking aid		V	V	V	V																																			
307	Driver informationCommunication	Radio		V	V	V	V											V																								
307	Driver informationCommunication	CD Player		V	V	V	V																																			
307	Driver informationCommunication	Instrument panel		V	V	V	V																																			
307	Driver informationCommunication	Switch module at the steering wheel		V	V		V																																			
307	VisibilityLighting	Driving school			V	V	V																																			
307	VisibilityLighting	Rain/sunlight sensor		V			V																																			
307	VisibilityLighting	Switch module at the steering wheel		V	V		V																																			
307	Airbag	Airbag ECU		V	V		V																																			
307	Roll-over ECU	Roll-over ECU		V	V		V																																			
307	Control the openings	Driver's door module		V	V		V																																			
307	Control the openings	Passenger's door module		V	V		V																																			
307	Control the openings	Folding roof		V	V	V	V																																			
307	Heating ventilation	Air conditioning ECU		V	V	V	V																																			
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4	V	V	V	V																											V		V					
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4	V	V	V	V																											V		V					
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5	V	V	V	V																											V		V					
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5	V	V	V	V																											V		V					
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000	V	V	V	V																											V		V					
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000	V	V	V	V																											V		V					
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000	V	V	V	V																											V		V					
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000	V	V	V	V																											V		V					
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM48P (Mechanical throttle housing)	V	V	V	V																											V							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM4MP2 (Motorised butterfly)	V	V	V	V																																			
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LP	V	V	V	V																																			
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFK MM6LP	V	V	V	V																																			
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP	V	V	V	V																																			
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3	V	V	V	V																																			
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3	V	V	V	V																																			
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4	V	V	V	V																																			
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3	V	V	V	V																																			V
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3	V	V	V	V																																			
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHS BOSCH EDC15C2	V	V	V	V																																			
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2	V	V	V	V																																			
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHZ BOSCH EDC15C2	V	V	V	V																																			
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801	V	V	V	V																																			
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHL SIEMENS SID 803	V	V	V	V																																			
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID 803	V	V	V	V																																			
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3	V	V	V	V																																			

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
307	Engines automatic gearbox	Diesel fuel additive control unit		V	V	V	V																																			
307	Engines automatic gearbox	AL4 gearbox		V	V	V	V																																			
307	Engines automatic gearbox	AL4 gearbox		V	V	V	V																																			
307	Active safety	ESP BOSCH 5.7		V	V	V	V																																			
307	Active safety	ABS BOSCH 8		V	V	V	V																																			
307	Active safety	ESP BOSCH 8		V	V	V	V																																			
307	Active safety	ABS 81		V	V	V	V																																			
307	Electric pump unit (power steering)	Power steering		V	V		V																																			
308	Driving assistance Comfort	Heating/ventilation		V	V	V	V																																			
308	Driving assistance Comfort	Power steering		V	V	V	V																																			
308	Driving assistance Comfort	Parking aid		V	V		V																																			
308	Built-In system interface	Built-In system interface		V																																						
308	Inform the driver Audio Communication	Multifunction display		V	V	V	V																																			
308	Inform the driver Audio Communication	Radio		V	V	V	V																																			
308	Inform the driver Audio Communication	Instrument panel		V	V	V	V																																			
308	Inform the driver Audio Communication	Warning light showing seat belt not fastened				V	V																																			
308	Inform the driver Audio Communication	Switch module at the steering wheel		V	V	V	V																																			
308	Inform the driver Audio Communication	Battery charge status unit		V	V		V																															V				
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4	V	V	V	V																																			
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4	V	V	V	V																																			
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4 EVO	V	V	V	V																																			
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX EDC16C3	V	V	V	V																																			
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY EDC16C3	V	V	V	V																																			
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3	V	V	V	V																																			
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3	V	V	V	V																																			
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4	V	V	V	V																																			
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4	V	V	V	V																																			
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4	V	V	V	V																																			
308	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox	V	V	V	V																																			
308	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox	V	V	V	V																																			
308	Engine Gearbox	Gearbox ECU	CFC300P gearbox	V	V	V	V																																			
308	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox	V	V	V	V																																			
308	Engine Gearbox	Multiplexed additive adding pump ECU		V	V	V	V																																			
308	Vehicle protection Management of accesses	Driver's door module		V	V	V	V																																			
308	Active and passive safety	ABS or ESP ECU		V	V	V	V																																			
308	Active and passive safety	Airbag ECU		V	V		V																																			
308	Visibility Lighting Signalling	Rain/sunlight sensor		V			V																																			
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4	V	V	V	V																																			
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4	V	V	V	V																																			
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4 EVO	V	V	V	V																																			

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	MED17_4_4	V	V	V	V																																			
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	EDC17C10_BR2	V	V	V	V																																			
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	EDC17C10_BR2	V	V	V	V																																			
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	SID807	V	V	V	V																																			
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	DCM3.5_BR2	V	V	V	V																																			
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX EDC16C3	V	V	V	V																																			
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY EDC16C3	V	V	V	V																																			
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3	V	V	V	V																																			
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3	V	V	V	V																																			
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4	V	V	V	V																																			
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4	V	V	V	V																																			
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4	V	V	V	V																																			
308(T9)	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox	V	V	V	V																																			
308(T9)	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox	V	V	V	V																																			
308(T9)	Engine Gearbox	Gearbox ECU	CFC300P gearbox	V	V	V	V																																			
308(T9)	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox	V	V	V	V																																			
308(T9)	Engine Gearbox	Gearbox ECU	BVA_AM6_AT6_UDS	V		V	V																																			
308(T9)	Engine Gearbox	Multiplexed additive adding pump ECU		V	V	V	V																																			
308(T9)	Headlamp height adjuster directional headlamp	LADCT		V	V	V	V																																			
308(T9)	Built-In system interface	Built-In system interface		V			V																																			
308(T9)	Switch module at the steering wheel	COM2008P		V	V	V	V																																			
308(T9)	ABS or ESP ECU	90 ESP		V	V	V	V																																			
308(T9)	ABS or ESP ECU	ESP 81		V	V	V	V																																			
308(T9)	ABS or ESP ECU	ESP MK 100		V	V	V	V																																			
308(T9)	Airbag ECU	RBG_UDS		V	V		V																																			
308(T9)	Engine relay unit	Engine relay unit		V	V	V	V																																			
308(T9)	Supply protection and management unit	BPGA2010			V		V																																			
308(T9)	Door control pad	PDPC_UDS		V	V	V	V																																			
308(T9)	Electric power steering	DAE_BVH2		V	V		V																																			
308(T9)	Telematics unit SMEG_PLUS	SMEG_PLUS		V	V	V	V																																			
308(T9)	Air conditioning	BCC		V	V	V	V																																			
308(T9)	Controls on the steering wheel	Controls on the steering wheel		V	V	V	V																																			
308(T9)	Touch screen	Touch screen		V	V	V	V																																			
308(T9)	Rain-sunlight sensor	CDPL_UDS_HELLA		V	V		V																																			
308(T9)	Seat belts not fastened LED unit	TNB_2010				V	V																																			
405	Engine(6th to 8th digit of VIN)	L6A SAGEM SL96		V	V	V	V																																	V		
405	Engine(6th to 8th digit of VIN)	1600RD SL96		V	V	V	V																																	V		
405	Engine(6th to 8th digit of VIN)	N6A BOSCH ME7.4.4		V	V	V	V																												V							
405	Engine(6th to 8th digit of VIN)	N6B BOSCH ME7.4.4		V	V	V	V																												V							
405	Engine(6th to 8th digit of VIN)	NFU BOSCH ME7.4.4		V	V	V	V																												V							

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
405	Engine(6th to 8th digit of VIN)	LFZ SAGEM S2000		V	V	V	V																												V							
405	Engine(6th to 8th digit of VIN)	LFZ SAGEM S2000		V	V	V	V																												V							
405	Engine(6th to 8th digit of VIN)	1600RD SAGEM S2000		V	V	V	V																												V							
405	Engine(6th to 8th digit of VIN)	1600RD SAGEM S2000		V	V	V	V																												V							
405	Engine(6th to 8th digit of VIN)	LFY BOSCH MP7.3		V	V	V	V																												V							
405	Engine(6th to 8th digit of VIN)	NFU J35		V	V	V	V																												V							
406	Built-in systems interface	Built-in systems interface		V	V	V	V															V																				
406	Alarm	Alarm		V		V	V																																			
406	Driver informationCommunication	Multifunction display		V																																						
406	Driver informationCommunication	Instrument panel		V	V	V	V																															V				
406	Driver informationCommunication	Radio		V	V	V	V											V																								
406	Driver informationCommunication	CD Player		V	V	V	V																																			
406	Driver informationCommunication	On-board navigation system		V	V		V																																			
406	VisibilityLighting	Rain/sunlight sensor		V			V																																			
406	Airbag	Airbag ECU		V	V		V																															V				
406	Heating ventilation	Air conditioning ECU		V	V	V	V																																			
406	Active safety	ABS BOSCH 5.3		V	V	V	V																																			
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	3FZ MM4MP2	V	V	V	V																																			
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	6FZ SAGEM S2000	V	V	V	V																												V							
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	6FZ SAGEM S2000	V	V	V	V																												V							
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	R6F MM 4.8P	V	V	V	V																												V							
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM 4.8P	V	V	V	V																												V							
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	XFX BOSCH ME 7.4.6	V	V	V	V																																			
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	4HX BOSCH EDC15C2	V	V	V	V																																			
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHS BOSCH EDC15C2	V	V	V	V																																			
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2	V	V	V	V																																			
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHZ BOSCH EDC15C2	V	V	V	V																																			
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801	V	V	V	V																																			
406	Engines automatic gearbox	Diesel fuel additive control unit		V	V	V	V																																			
406	Engines automatic gearbox	Automatic gearbox		V	V	V	V																																			
406	Engines automatic gearbox	Automatic gearbox		V	V	V	V																																			
407	Driving assistance Comfort	Parking aid		V	V	V	V																															V				
407	Driving assistance Comfort	Heating/ventilation		V	V	V	V																																			
407	Driving assistance Comfort	Under inflation detection		V	V		V																																			
407	Driving assistance Comfort	Power steering		V	V	V	V																																			
407	Built-In system interface	Built-In system interface		V																																						
407	Inform the driver Audio Communication	Multifunction display	TYPE 'C'(DOT MATRIX)	V	V	V	V																																			
407	Inform the driver Audio Communication	Multifunction display	TYPE 'C COLOUR'(DOT MATRIX)	V			V																																			
407	Inform the driver Audio Communication	Radio		V	V	V	V																																			
407	Inform the driver Audio Communication	CD player		V		V	V																																			

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
407	Inform the driver Audio Communication	Instrument panel		V	V	V	V																																			
407	Inform the driver Audio Communication	Switch module at the steering wheel		V	V	V	V																																			
407	Inform the driver Audio Communication	Telematics		V	V	V	V																																			
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	XFV ME747	V	V	V	V																											V								
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	3FZ MM6LP	V	V	V	V																																			
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP	V	V	V	V																																			
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3	V	V	V	V																																			
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4	V	V	V	V																																			
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4	V	V	V	V																																			
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4	V	V	V	V																																			
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL SIEMENS SID 803	V	V	V	V																																			
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID 803	V	V	V	V																																			
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	UHZ SID 201	V	V	V	V																																			
407	Engine Gearbox	Diesel fuel additive control unit		V	V	V	V																																			
407	Engine Gearbox	Gearbox ECU	AM6 automatic gearbox	V	V	V	V																																			
407	Engine Gearbox	Gearbox ECU	BVA_AL4_AT8	V	V	V	V																																			
407	Engine Gearbox	Gearbox ECU	BVA_AL4_AT8	V	V	V	V																																			
407	Vehicle protection Management of accesses	Driver's door module		V	V	V	V																																			
407	Vehicle protection Management of accesses	Passenger's door module		V	V	V	V																																			
407	Vehicle protection Management of accesses	Sun roof		V	V	V	V																																			
407	Active and passive safety	ABS or ESP ECU		V	V	V	V																																			
407	Active and passive safety	ABS or ESP ECU		V	V	V	V																																			
407	Active and passive safety	Airbag ECU		V	V		V																																			
407	Visibility Lighting Signalling	Control unit Windscreen wipers		V	V	V	V																																			
407	Visibility Lighting Signalling	Rain/sunlight sensor		V			V																																			
3008	Driving assistance Comfort	High Head Vision		V	V	V	V																																			
3008	Driving assistance Comfort	Assistance in complying with the inter-vehicle time (ARTIV)		V	V		V																																			
3008	Driving assistance Comfort	Air conditioning ECU		V	V	V	V																																			
3008	Driving assistance Comfort	Parking aid		V	V		V																																			
3008	Driving assistance Comfort	Electropump assembly		V	V	V	V																																			
3008	Driving assistance Comfort	Under inflation detection		V	V		V																																			
3008	Driving assistance Comfort	Electric parking brake		V	V	V	V																																			
3008	Built-In system interface	Built-In system interface		V																																						
3008	Inform the driver Audio Communication	Multifunction display (EMF)		V	V	V	V																																			
3008	Inform the driver Audio Communication	Switch module at the steering wheel		V	V	V	V																																			
3008	Inform the driver Audio Communication	Radio		V	V	V	V																																			
3008	Inform the driver Audio Communication	Instrument panel		V	V	V	V																																			
3008	Inform the driver Audio Communication	Control panel dot matrix display		V	V	V	V																																			
3008	Inform the driver Audio Communication	Battery charge status unit		V	V		V																															V				
3008	Inform the driver Audio Communication	Not Fastened warning light (TNB)				V	V																																			

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4	V	V	V	V																																			
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4	V	V	V	V																																			
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FX MED 17.4	V	V	V	V																																			
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FV MED 17.4	V	V	V	V																																			
3008	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3	V	V	V	V																																			
3008	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HD HDI_SID807_BR2	V	V	V	V																																			
3008	Engine Gearbox	Gearbox ECU	CFC300P gearbox	V	V	V	V																																			
3008	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox	V	V	V	V																																			
3008	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox	V	V	V	V																																			
3008	Engine Gearbox	Multiplexed additive adding pump ECU		V	V	V	V																																			
3008	Vehicle protection Management of accesses	Driver's door module		V	V	V	V																																			
3008	Active and passive safety	ABS or ESP ECU		V	V	V	V																																			
3008	Active and passive safety	Airbag ECU		V	V		V																																			
3008	Visibility Lighting Signalling	Rain sensor		V			V																																			
3008	Visibility Lighting Signalling	Windscreen wiper		V	V	V	V																																			
5008	Driving assistance Comfort	Power steering		V		V	V																																			
5008	Driving assistance Comfort	Parking aid		V	V	V	V																															V				
5008	Built-In system interface	Built-In system interface		V																																						
5008	Inform the driver Audio Communication	Multifunction display		V	V	V	V																																			
5008	Inform the driver Audio Communication	Radio		V	V	V	V																																			
5008	Inform the driver Audio Communication	Instrument panel		V	V	V	V																															V				
5008	Inform the driver Audio Communication	Switch module at the steering wheel		V	V	V	V																																			
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4	V	V	V	V																																			
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4	V	V	V	V																																			
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO	V	V	V	V																																			
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5	V	V	V	V																																			
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21	V	V	V	V																																			
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3	V	V	V	V																																			
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3	V	V	V	V																																			
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3	V	V	V	V																																			
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3	V	V	V	V																																			
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4	V	V	V	V																																			
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HR HDI SID807	V	V	V	V																																			
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR SIEMENS SID803A	V	V	V	V																																			
5008	Engine Gearbox	Gearbox ECU	Auto gearbox AL4	V	V	V	V																																			
5008	Engine Gearbox	Gearbox ECU	AM6 Euro5	V	V	V	V																																			
5008	Engine Gearbox	Gearbox ECU	AT6 Euro5	V	V	V	V																																			
5008	Engine Gearbox	Gearbox ECU	CFC300P	V	V	V	V																																			
5008	Engine Gearbox	Gearbox ECU	BVA_AT8	V	V	V	V																																			
5008	Vehicle protection Management of accesses	Engine relay unit		V																																						

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
5008	Vehicle protection Management of accesses	Trailer relay unit		V																																						
5008	Vehicle protection Management of accesses	Windscreen wiper		V	V	V	V																																			
5008	Active and passive safety	ABS or ESP ECU		V	V	V	V																																			
5008	Active and passive safety	Electric secondary brake		V	V	V	V																																			
5008	Active and passive safety	Airbag ECU		V	V		V																															V				
PARTNER	Driving assistance Comfort	Parking aid		V	V	V	V																																			
PARTNER	Built-In system interface	Built-In system interface		V	V	V	V																																			
PARTNER	Driver information Communication	Display / Telematics		V																																						
PARTNER	Driver information Communication	Radio		V	V	V	V											V																								
PARTNER	Driver information Communication	CD Player		V	V	V	V																																			
PARTNER	Driver information Communication	Instrument panel		V	V	V	V																																			
PARTNER	Driver information Communication	Switching module below steering wheel (COM 2000)		V	V		V																																			
PARTNER	Airbags	Airbags		V	V		V																															V				
PARTNER	VisibilityLighting	Switching module below steering wheel (COM 2000)		V	V		V																																			
PARTNER	VisibilityLighting	Rain/sunlight sensor		V			V																																			
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P	V	V	V	V																												V							
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2	V	V	V	V																												V			V				
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2	V	V	V	V																												V			V				
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4	V	V	V	V																												V			V				
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4	V	V	V	V																												V			V				
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5	V	V	V	V																												V			V				
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6B BOSCH ME7.4.5	V	V	V	V																												V			V				
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5	V	V	V	V																												V			V				
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU or N6A BOSCH ME749	V	V	V	V																												V							
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749 BIO FLEX	V	V	V	V																												V							
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME749	V	V	V	V																												V							
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME749 BIO FLEX	V	V	V	V																												V							
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P	V	V	V	V																												V	V	V					
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID801	V	V	V	V																																			
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2	V	V	V	V																																			
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4	V	V	V	V																																			
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3	V	V	V	V																																			
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3	V	V	V	V																																			
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HW BOSCH EDC16C3	V	V	V	V																																			
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3	V	V	V	V																																			V
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2	V	V	V	V																																			
PARTNER	Active Safety	ESP BOSCH 5.7		V	V	V	V																																			
PARTNER	Active Safety	ABS BOSCH 8		V	V	V	V																																			
PARTNER	Active Safety	ESP BOSCH 8		V	V	V	V																																			
PARTNER	Active Safety	ABS 8.1		V	V	V	V																																			

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
PARTNER	Active Safety	ESP 8.1		V	V	V	V																																			
PARTNER B9	Driving assistance Comfort	Power steering		V		V	V																																			
PARTNER B9	Driving assistance Comfort	Parking aid		V	V		V																																			
PARTNER B9	Built-In system interface	Built-In system interface		V																																						
PARTNER B9	Inform the driver Audio Communication	Multifunction display		V	V	V	V																																			
PARTNER B9	Inform the driver Audio Communication	Bodywork conversion unit		V	V		V																																			
PARTNER B9	Inform the driver Audio Communication	Instrument panel		V	V	V	V																															V				
PARTNER B9	Inform the driver Audio Communication	Switch module at the steering wheel		V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HF-DV6DTED-89 CV	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HF-DV6DTED-89 CV	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HE-DV6DTED-89 CV	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HE-DV6DTED-89 CV	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	HDI_SID807_BR2 HDI_SID807_BR2 9HL	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 NFU	V	V	V	V																												V							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 N6B	V	V	V	V																												V							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 N6A	V	V	V	V																												V							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 NFR	V	V	V	V																												V							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HR HDI SID807	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR SIEMENS SID803A	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Gearbox ECU	Auto gearbox AL4	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Gearbox ECU	AM6 Euro5	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Gearbox ECU	AT6 Euro5	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Gearbox ECU	CFC300P	V	V	V	V																																			
PARTNER B9	Engine Gearbox	Gearbox ECU	BVA_AT8	V	V	V	V																																			
PARTNER B9	Vehicle protection Management of accesses	Engine relay unit		V																																						
PARTNER B9	Vehicle protection Management of accesses	Trailer relay unit		V																																						
PARTNER B9	Vehicle protection Management of accesses	Windscreen wiper		V	V	V	V																																			
PARTNER B9	Active and passive safety	ABS or ESP ECU	ESP 81	V	V	V	V																																			
PARTNER B9	Active and passive safety	ABS or ESP ECU	ESP MK 100	V	V	V	V																																			
PARTNER B9	Active and passive safety	ABS or ESP ECU	90 ESP	V	V	V	V																																			

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
PARTNER B9	Active and passive safety	Electric secondary brake		V	V	V	V																																			
PARTNER B9	Active and passive safety	Airbag ECU		V	V		V																															V			
BOXER	Engine(6th to 8th digit of VIN)	BMF PUMA	BMF HDI 4C	V	V	V	V																																		
BOXER	Engine(6th to 8th digit of VIN)	EDC17CP52_UDS 3.0 HDI 180CV E5	EDC17CP52_UDS 3.0 HDI 180CV E5	V	V	V	V																																		
BOXER	Engine(6th to 8th digit of VIN)	SID208	SID208	V	V	V	V																																		
BOXER	ABSESP	ESP 90_F		V	V	V	V																																		
BOXER	ABSESP	ESP 81		V	V	V	V																																		
BOXER	ABSESP	ABS 81		V	V	V	V																																		
BOXER	Built-In system interface	Built-In system interface		V																																					
BOXER	Built-In system interface	Built-In system interface		V	V		V																																		
BOXER	LDWS	LDWS		V	V		V																																		
BIPPER	Engine(6th to 8th digit of VIN)	EDC16C34		V	V	V	V																																		
BIPPER	Engine(6th to 8th digit of VIN)	HDI_8DF3		V	V	V	V																																		
BIPPER	Engine(6th to 8th digit of VIN)	BMF PUMA	BMF HDI 4C	V	V	V	V																																		
BIPPER	Engine(6th to 8th digit of VIN)	EDC17CP52_UDS 3.0 HDI 180CV E5		V	V	V	V																																		
BIPPER	Engine(6th to 8th digit of VIN)	SID208		V	V	V	V																																		
BIPPER	ABSESP	ESP 90_F		V	V	V	V																																		
BIPPER	ABSESP	ESP 81		V	V	V	V																																		
BIPPER	ABSESP	ABS 81		V	V	V	V																																		
BIPPER	Built-In system interface	Built-In system interface		V			V																																		
BIPPER	Built-In system interface	Built-In system interface		V																																					
BIPPER	Built-In system interface	Built-In system interface		V	V		V																																		
BIPPER	Airbag	Airbag		V			V																																		
BIPPER	LDWS	LDWS		V	V		V																																		
BIPPER	Instrument	Instrument		V			V																																		
BIPPER	Parking control	Parking control		V			V																																		
EXPERT	Engine(6th to 8th digit of VIN)	EDC17C10_BR2		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	EDC17C10_BR2		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	DCM3.5_BR2		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	SID807		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	5FW MEV 17.4		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	8FS MEV 17.4		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	MED17_4_4		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	9HX EDC16C3		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	9HY EDC16C3		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	9HZ EDC16C3		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	9HV EDC16C3		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	RHR DCM 3.4		V	V	V	V																																		
EXPERT	Engine(6th to 8th digit of VIN)	RHL DCM 3.4		V	V	V	V																																		

Vehicle	System 1	System 2	System 3	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Motorised throttle valve programming	Setting of the clutch actuator to the removal/refitting position	Clutch and gearbox actuator programming	Pairing of the esp ecu and engine management ecu	Key Code Erasure	Key Code Registration(With Master Key)	Torque Sensor Adjustment	Rotational Angle Sensor Calibration	ECUs Present	Maintenance	VIN code	Programming by default	customer mode	Engine immobiliser code and key	Resetting to zero	[Option] Heating/ventilition	[Option] Warnings	[Option] Lighting/Signaling	[Option] Visibility	[Option] Opening and access	[Option] Engine compartment	[Option] Passenger compartment	[Option] Locking/Unlocking	[Option] Fuel information	[Option] Miscellaneous	[Option] Alarm	[Option] Show-Room	Initialising the autoadaptives	Configuration View Only	Auto Configuration	Configuration	Initial Autoadaptive	Adjust Emission Control	Configuration Of The Amount Of Additive In The DPF
EXPERT	Engine(6th to 8th digit of VIN)	RHF DCM 3.4		V	V	V	V																																			
EXPERT	Gearbox ECU	AM6 Euro5 automatic gearbox		V	V	V	V																																			
EXPERT	Gearbox ECU	AT6 Euro5 automatic gearbox		V	V	V	V																																			
EXPERT	Gearbox ECU	CFC300P gearbox		V	V	V	V																																			
EXPERT	Gearbox ECU	AL4 automatic gearbox		V	V	V	V																																			
EXPERT	Gearbox ECU	BVA_AM6_AT6_UDS		V		V	V																																			
EXPERT	Multiplexed additive adding pump ECU	Multiplexed additive adding pump ECU		V	V	V	V																																			
EXPERT	ABS or ESP ECU	ESP 81		V	V	V	V																																			
EXPERT	ABS or ESP ECU	90 ESP		V	V	V	V																																			
EXPERT	ABS or ESP ECU	ESP MK 100		V	V	V	V																																			
EXPERT	Headlamp height adjuster directional headlamp	Headlamp height adjuster/ directional headlamp		V	V	V	V																																			
EXPERT	Built-In system interface	Built-In system interface		V			V																																			
EXPERT	Built-In system interface	Built-In system interface		V																																						
EXPERT	Power steering electric pump unit	GEP		V		V	V																																			
EXPERT	Power steering electric pump unit	DAE_BVH2		V	V		V																																			
EXPERT	Battery charge status unit	BECB_GEN2		V	V		V																															V				
EXPERT	Electric secondary brake	FSE		V	V	V	V																																			
EXPERT	Engine relay unit	BSM		V	V	V	V																																			
EXPERT	Trailer relay unit	BSR		V																																						
EXPERT	Airbag ECU	RBG_UDS		V	V		V																																			
EXPERT	Airbag ECU	RBG_UDS		V	V		V																																			
EXPERT	Airbag ECU	SAC_AUTOLIV		V	V		V																															V				
EXPERT	Instrument panel	COMBINE		V	V	V	V																																			
EXPERT	Instrument panel	COMBINE		V	V	V	V																															V				
EXPERT	Rain-sunlight sensor	Rain and brightness sensor		V			V																																			
EXPERT	Rain-sunlight sensor	CDPL_UDS_HELLA		V	V		V																																			
EXPERT	Switch module at the steering wheel	COM2008P		V	V	V	V																																			
EXPERT	Switch module at the steering wheel	HDC		V	V	V	V																																			
EXPERT	Bodywork conversion unit	BTC		V	V		V																																			
EXPERT	Parking aid	AAS		V	V		V																																			
EXPERT	Additional heating	CHAUFF_ADD		V	V	V	V																																			
EXPERT	Telematics unit	SMEG_PLUS		V	V	V	V																																			
EXPERT	Anti-theft alarm	ALARME		V		V	V																																			
EXPERT	Rear air conditioning table	TAB_CLIM_AR		V	V	V	V																																			
EXPERT	Rain and brightness sensor	PLUIE_LUMINOSITE		V			V																																			
EXPERT	Supply protection and management unit	BPGA2010			V		V																																			
EXPERT	Door control pad	PDPC_UDS		V	V	V	V																																			
EXPERT	Air conditioning	BCC		V	V	V	V																																			
EXPERT	Touch screen	Touch screen		V	V	V	V																																			
EXPERT	Seat belts not fastened LED unit	TNB_2010				V	V																																			

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
107	Engine ECU	Petrol engine	ME795																																						
107	Gearbox ECU	MMT																																							
107	Airbag	Airbag																																							
107	ABS or ESP	ABS or ESP																																							
107	Coded anti-start	ADC																																							
107	Power steering	DAE																																							
206	Built-In system interface	Built-In system interface																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	7LZ MM5NP																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	HFX J34P																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D J34P																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFX BOSCH MP7.3																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFX MM1AP																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME7.4.4																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME7.4.4 FLEX FUEL																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW ME749																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW ME749 BIOFLEX																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4 FLEX FUEL																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4 FLEX FUEL																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU or N6A or N6B ME749 BIO FLEX																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU J35																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM4.8P																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HX/8HZ BOSCH EDC16C3 EURO3																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																																						

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3																																						
206	Engines automatic gearbox	Diesel fuel additive control unit																																							
206	Engines automatic gearbox	AL4 automatic gearbox		V	V																																				
206	Engines automatic gearbox	AL4 automatic gearbox		V	V																																				
206	Alarm	Alarm				V																																			
206	Driver informationCommunication	Display/Telematics (AMF)																																							
206	Driver informationCommunication	Display/Telematics (RT3)					V	V	V	V	V	V	V	V																											
206	Driver informationCommunication	Radio													V																										
206	Driver informationCommunication	CD Player														V																									
206	Driver informationCommunication	Instrument panel															V																								
206	Driver informationCommunication	Switching module steering wheel																																							
206	Driver informationCommunication	On-board navigation system																																							
206	VisibilityLighting	Driving school																																							
206	VisibilityLighting	Rain/sunlight sensor																																							
206	Airbag	Airbag SAC Central																V	V	V																					
206	Control the openings	Electric retractable roof																			V																				
206	Heatingventilation	A/C																				V																			
206	Active safety	ABS TEVES MK20																					V	V																	
206	Active safety	ABS MK70																							V	V	V	V	V												
206	Active safety	ESP MK60																																							
206	Electric pump unit (power steering)	Power steering																																							
207	Driving assistance Comfort	Parking aid																																							
207	Driving assistance Comfort	Heating/ventilation																																							
207	Driving assistance Comfort	Under inflation detection																																							
207	Driving assistance Comfort	Power steering																																							
207	Built-In system interface	Built-In system interface																																							
207	Inform the driver Audio Communication	Multifunction display																												V	V	V	V	V							
207	Inform the driver Audio Communication	Radio																																							
207	Inform the driver Audio Communication	CD player																																							
207	Inform the driver Audio Communication	Instrument panel																																	V						
207	Inform the driver Audio Communication	Switch module at the steering wheel																																							
207	Inform the driver Audio Communication	Warning light showing seat belt not fastened																																							
207	Inform the driver Audio Communication	Battery charge status unit																																							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																																						
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6B BOSCH ME7.4.5																																						
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																																						
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FX MED 17.4																																	V					
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FY MED 17.4																																	V					

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LPC																																		V				
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																																	V					
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4																																	V					
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV17.4																																	V					
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FR MEV17.4																																	V					
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FR MED17.4																																	V					
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C3																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HL HDI SID807																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HR HDI SID807																																						
207	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox																																						
207	Engine Gearbox	Gearbox ECU	Controlled manual gearbox (BVMP_MA)																																		V	V	V	V
207	Engine Gearbox	Gearbox ECU	CFC300P																																						
207	Vehicle protection Management of accesses	Folding roof																																							
207	Active and passive safety	ABS or ESP ECU																																							
207	Active and passive safety	Airbag ECU																																							
207	Visibility Lighting Signalling	Rain/sunlight sensor																																							
207	Visibility Lighting Signalling	Static AFS																																							
207	Visibility Lighting Signalling	Switch module at the steering wheel																																							
208	Driving assistance Comfort	Electric power steering																																							
208	Built-In system interface	Built-In system interface																																							
208	Inform the driver Audio Communication	Multiplexed control panel																																							
208	Inform the driver Audio Communication	External CD player																																							
208	Inform the driver Audio Communication	Air conditioning																																							
208	Inform the driver Audio Communication	Instrument panel																																							
208	Inform the driver Audio Communication	Switch module at the steering wheel																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HP DV6DTED 92 CV																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HP DV6DTED 92 CV																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME749_EC5																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																	V					
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																	V					
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																	V					
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																						

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																						
208	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																						
208	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																						
208	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																						
208	Engine Gearbox	Gearbox ECU	BVA_AL4																																						
208	Active and passive safety	ABS or ESP ECU																																							
208	Active and passive safety	Airbag ECU																																							
301	Driving assistance Comfort	Power steering																																							
301	Driving assistance Comfort	Parking aid																																							
301	Built-In system interface	Built-In system interface																																							
301	Inform the driver Audio Communication	Multifunction display																												V	V	V	V	V							
301	Inform the driver Audio Communication	Radio																																							
301	Inform the driver Audio Communication	Instrument panel																																							
301	Inform the driver Audio Communication	Switch module at the steering wheel																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																V						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																V						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																V						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																						
301	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																						
301	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																						
301	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																						
301	Engine Gearbox	Gearbox ECU	BVA_AT8																																						
301	Vehicle protection Management of accesses	Driver's door module																																							
301	Active and passive safety	ABS or ESP ECU																																							
301	Active and passive safety	Airbag ECU																																							
307	Built-in systems interface	Built-in systems interface																																							
307	Alarm	Alarm				V																																			

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
307	Driver informationCommunication	Multifunction display																																							
307	Driver informationCommunication	Parking aid																																							
307	Driver informationCommunication	Radio													V																										
307	Driver informationCommunication	CD Player														V																									
307	Driver informationCommunication	Instrument panel																																							
307	Driver informationCommunication	Switch module at the steering wheel																																							
307	VisibilityLighting	Driving school																																							
307	VisibilityLighting	Rain/sunlight sensor																																							
307	VisibilityLighting	Switch module at the steering wheel																																							
307	Airbag	Airbag ECU																																							
307	Roll-over ECU	Roll-over ECU																																							
307	Control the openings	Driver's door module																																							
307	Control the openings	Passenger's door module																																							
307	Control the openings	Folding roof																																							
307	Heating ventilation	Air conditioning ECU																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM48P (Mechanical throttle housing)																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM4MP2 (Motorised butterfly)																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHS BOSCH EDC15C2																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHZ BOSCH EDC15C2																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHL SIEMENS SID 803																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID 803																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3																																						

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
307	Engines automatic gearbox	Diesel fuel additive control unit																																							
307	Engines automatic gearbox	AL4 gearbox		V	V																																				
307	Engines automatic gearbox	AL4 gearbox		V	V																																				
307	Active safety	ESP BOSCH 5.7																																							
307	Active safety	ABS BOSCH 8																																							
307	Active safety	ESP BOSCH 8																																							
307	Active safety	ABS 81																																							
307	Electric pump unit (power steering)	Power steering																																							
308	Driving assistance Comfort	Heating/ventilation																																							
308	Driving assistance Comfort	Power steering																																							
308	Driving assistance Comfort	Parking aid																																							
308	Built-In system interface	Built-In system interface																																							
308	Inform the driver Audio Communication	Multifunction display																												V	V	V	V	V							
308	Inform the driver Audio Communication	Radio																																							
308	Inform the driver Audio Communication	Instrument panel																																V							
308	Inform the driver Audio Communication	Warning light showing seat belt not fastened																																							
308	Inform the driver Audio Communication	Switch module at the steering wheel																																							
308	Inform the driver Audio Communication	Battery charge status unit																																							
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																																V						
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4																																V						
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																V						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX EDC16C3																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY EDC16C3																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4																																						
308	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																						
308	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																						
308	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																						
308	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox																																						
308	Engine Gearbox	Multiplexed additive adding pump ECU																																							
308	Vehicle protection Management of accesses	Driver's door module																																							
308	Active and passive safety	ABS or ESP ECU																																							
308	Active and passive safety	Airbag ECU																																							
308	Visibility Lighting Signalling	Rain/sunlight sensor																																							
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																																V						
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4																																V						
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																V						

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	MED17_4_4																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	EDC17C10_BR2																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	EDC17C10_BR2																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	SID807																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	DCM3.5_BR2																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX EDC16C3																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY EDC16C3																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4																																						
308(T9)	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																						
308(T9)	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																						
308(T9)	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																						
308(T9)	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox																																						
308(T9)	Engine Gearbox	Gearbox ECU	BVA_AM6_AT6_UDS																																						
308(T9)	Engine Gearbox	Multiplexed additive adding pump ECU																																							
308(T9)	Headlamp height adjuster directional headlamp	LADCT																																							
308(T9)	Built-In system interface	Built-In system interface																																							
308(T9)	Switch module at the steering wheel	COM2008P																																							
308(T9)	ABS or ESP ECU	90 ESP																											V												
308(T9)	ABS or ESP ECU	ESP 81																																							
308(T9)	ABS or ESP ECU	ESP MK 100																																							
308(T9)	Airbag ECU	RBG_UDS																																							
308(T9)	Engine relay unit	Engine relay unit																																							
308(T9)	Supply protection and management unit	BPGA2010																																							
308(T9)	Door control pad	PDPC_UDS																																							
308(T9)	Electric power steering	DAE_BVH2																																							
308(T9)	Telematics unit SMEG_PLUS	SMEG_PLUS																																							
308(T9)	Air conditioning	BCC																																							
308(T9)	Controls on the steering wheel	Controls on the steering wheel																																							
308(T9)	Touch screen	Touch screen																																							
308(T9)	Rain-sunlight sensor	CDPL_UDS_HELLA																																							
308(T9)	Seat belts not fastened LED unit	TNB_2010																																							
405	Engine(6th to 8th digit of VIN)	L6A SAGEM SL96																																							
405	Engine(6th to 8th digit of VIN)	1600RD SL96																																							
405	Engine(6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																																							
405	Engine(6th to 8th digit of VIN)	N6B BOSCH ME7.4.4																																							
405	Engine(6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																							

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
405	Engine(6th to 8th digit of VIN)	LFZ SAGEM S2000																																							
405	Engine(6th to 8th digit of VIN)	LFZ SAGEM S2000																																							
405	Engine(6th to 8th digit of VIN)	1600RD SAGEM S2000																																							
405	Engine(6th to 8th digit of VIN)	1600RD SAGEM S2000																																							
405	Engine(6th to 8th digit of VIN)	LFY BOSCH MP7.3																																							
405	Engine(6th to 8th digit of VIN)	NFU J35																																							
406	Built-in systems interface	Built-in systems interface																																							
406	Alarm	Alarm				V																																			
406	Driver informationCommunication	Multifunction display																																							
406	Driver informationCommunication	Instrument panel																																							
406	Driver informationCommunication	Radio													V																										
406	Driver informationCommunication	CD Player														V																									
406	Driver informationCommunication	On-board navigation system																																							
406	VisibilityLighting	Rain/sunlight sensor																																							
406	Airbag	Airbag ECU																																							
406	Heating ventilation	Air conditioning ECU																																							
406	Active safety	ABS BOSCH 5.3																																							
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	3FZ MM4MP2																																						
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	6FZ SAGEM S2000																																						
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	6FZ SAGEM S2000																																						
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	R6F MM 4.8P																																						
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM 4.8P																																						
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	XFX BOSCH ME 7.4.6																																						
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	4HX BOSCH EDC15C2																																						
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHS BOSCH EDC15C2																																						
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																						
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHZ BOSCH EDC15C2																																						
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801																																						
406	Engines automatic gearbox	Diesel fuel additive control unit																																							
406	Engines automatic gearbox	Automatic gearbox		V	V																																				
406	Engines automatic gearbox	Automatic gearbox		V	V																																				
407	Driving assistance Comfort	Parking aid																																							
407	Driving assistance Comfort	Heating/ventilation																																							
407	Driving assistance Comfort	Under inflation detection																																							
407	Driving assistance Comfort	Power steering																																							
407	Built-In system interface	Built-In system interface																																							
407	Inform the driver Audio Communication	Multifunction display	TYPE 'C'(DOT MATRIX)																											V	V	V	V	V							
407	Inform the driver Audio Communication	Multifunction display	TYPE 'C COLOUR'(DOT MATRIX)																																						
407	Inform the driver Audio Communication	Radio																																							
407	Inform the driver Audio Communication	CD player																																							

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
407	Inform the driver Audio Communication	Instrument panel																																	V						
407	Inform the driver Audio Communication	Switch module at the steering wheel																																							
407	Inform the driver Audio Communication	Telematics																																							
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	XFV ME747																																						
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	3FZ MM6LP																																						
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL SIEMENS SID 803																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID 803																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	UHZ SID 201																																						
407	Engine Gearbox	Diesel fuel additive control unit																																							
407	Engine Gearbox	Gearbox ECU	AM6 automatic gearbox																																						
407	Engine Gearbox	Gearbox ECU	BVA_AL4_AT8	V	V																																				
407	Engine Gearbox	Gearbox ECU	BVA_AL4_AT8	V	V																																				
407	Vehicle protection Management of accesses	Driver's door module																																							
407	Vehicle protection Management of accesses	Passenger's door module																																							
407	Vehicle protection Management of accesses	Sun roof																																							
407	Active and passive safety	ABS or ESP ECU																																							
407	Active and passive safety	ABS or ESP ECU																																							
407	Active and passive safety	Airbag ECU																																							
407	Visibility Lighting Signalling	Control unit Windscreen wipers																																							
407	Visibility Lighting Signalling	Rain/sunlight sensor																																							
3008	Driving assistance Comfort	High Head Vision																																							
3008	Driving assistance Comfort	Assistance in complying with the inter-vehicle time (ARTIV)																																							
3008	Driving assistance Comfort	Air conditioning ECU																																							
3008	Driving assistance Comfort	Parking aid																																							
3008	Driving assistance Comfort	Electropump assembly																																							
3008	Driving assistance Comfort	Under inflation detection																																							
3008	Driving assistance Comfort	Electric parking brake																																							
3008	Built-In system interface	Built-In system interface																																							
3008	Inform the driver Audio Communication	Multifunction display (EMF)																												V	V	V	V	V							
3008	Inform the driver Audio Communication	Switch module at the steering wheel																																							
3008	Inform the driver Audio Communication	Radio																																							
3008	Inform the driver Audio Communication	Instrument panel																																							
3008	Inform the driver Audio Communication	Control panel dot matrix display																																							
3008	Inform the driver Audio Communication	Battery charge status unit																																							
3008	Inform the driver Audio Communication	Not Fastened warning light (TNB)																																							

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																																V						
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4																																V						
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FX MED 17.4																																V						
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FV MED 17.4																																V						
3008	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3																																						
3008	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HD HDI_SID807_BR2																																						
3008	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																						
3008	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																						
3008	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																						
3008	Engine Gearbox	Multiplexed additive adding pump ECU																																							
3008	Vehicle protection Management of accesses	Driver's door module																																							
3008	Active and passive safety	ABS or ESP ECU																																							
3008	Active and passive safety	Airbag ECU																																							
3008	Visibility Lighting Signalling	Rain sensor																																							
3008	Visibility Lighting Signalling	Windscreen wiper																																							
5008	Driving assistance Comfort	Power steering																																							
5008	Driving assistance Comfort	Parking aid																																							
5008	Built-In system interface	Built-In system interface																																							
5008	Inform the driver Audio Communication	Multifunction display																																							
5008	Inform the driver Audio Communication	Radio																																							
5008	Inform the driver Audio Communication	Instrument panel																																V							
5008	Inform the driver Audio Communication	Switch module at the steering wheel																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																V						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																V						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																V						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HR HDI SID807																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR SIEMENS SID803A																																						
5008	Engine Gearbox	Gearbox ECU	Auto gearbox AL4																																						
5008	Engine Gearbox	Gearbox ECU	AM6 Euro5																																						
5008	Engine Gearbox	Gearbox ECU	AT6 Euro5																																						
5008	Engine Gearbox	Gearbox ECU	CFC300P																																						
5008	Engine Gearbox	Gearbox ECU	BVA_AT8																																						
5008	Vehicle protection Management of accesses	Engine relay unit																																							

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
5008	Vehicle protection Management of accesses	Trailer relay unit																																							
5008	Vehicle protection Management of accesses	Windscreen wiper																																							
5008	Active and passive safety	ABS or ESP ECU																																							
5008	Active and passive safety	Electric secondary brake																																							
5008	Active and passive safety	Airbag ECU																																							
PARTNER	Driving assistance Comfort	Parking aid																																							
PARTNER	Built-In system interface	Built-In system interface																																							
PARTNER	Driver information Communication	Display / Telematics																																							
PARTNER	Driver information Communication	Radio													V																										
PARTNER	Driver information Communication	CD Player														V																									
PARTNER	Driver information Communication	Instrument panel																																							
PARTNER	Driver information Communication	Switching module below steering wheel (COM 2000)																																							
PARTNER	Airbags	Airbags																																							
PARTNER	VisibilityLighting	Switching module below steering wheel (COM 2000)																																							
PARTNER	VisibilityLighting	Rain/sunlight sensor																																							
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6B BOSCH ME7.4.5																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU or N6A BOSCH ME749																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749 BIO FLEX																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME749																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME749 BIO FLEX																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID801																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HW BOSCH EDC16C3																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																						
PARTNER	Active Safety	ESP BOSCH 5.7																																							
PARTNER	Active Safety	ABS BOSCH 8																																							
PARTNER	Active Safety	ESP BOSCH 8																																							
PARTNER	Active Safety	ABS 8.1																																							

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
PARTNER	Active Safety	ESP 8.1																																							
PARTNER B9	Driving assistance Comfort	Power steering																																							
PARTNER B9	Driving assistance Comfort	Parking aid																																							
PARTNER B9	Built-In system interface	Built-In system interface																																							
PARTNER B9	Inform the driver Audio Communication	Multifunction display																																							
PARTNER B9	Inform the driver Audio Communication	Bodywork conversion unit																																							
PARTNER B9	Inform the driver Audio Communication	Instrument panel																																V							
PARTNER B9	Inform the driver Audio Communication	Switch module at the steering wheel																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HF-DV6DTED-89 CV																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HF-DV6DTED-89 CV																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HE-DV6DTED-89 CV																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HE-DV6DTED-89 CV																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	HDI_SID807_BR2 HDI_SID807_BR2 9HL																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 NFU																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 N6B																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 N6A																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 NFR																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																V						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																V						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																V						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HR HDI SID807																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR SIEMENS SID803A																																						
PARTNER B9	Engine Gearbox	Gearbox ECU	Auto gearbox AL4																																						
PARTNER B9	Engine Gearbox	Gearbox ECU	AM6 Euro5																																						
PARTNER B9	Engine Gearbox	Gearbox ECU	AT6 Euro5																																						
PARTNER B9	Engine Gearbox	Gearbox ECU	CFC300P																																						
PARTNER B9	Engine Gearbox	Gearbox ECU	BVA_AT8																																						
PARTNER B9	Vehicle protection Management of accesses	Engine relay unit																																							
PARTNER B9	Vehicle protection Management of accesses	Trailer relay unit																																							
PARTNER B9	Vehicle protection Management of accesses	Windscreen wiper																																							
PARTNER B9	Active and passive safety	ABS or ESP ECU	ESP 81																																						
PARTNER B9	Active and passive safety	ABS or ESP ECU	ESP MK 100																																						
PARTNER B9	Active and passive safety	ABS or ESP ECU	90 ESP																										V												

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
PARTNER B9	Active and passive safety	Electric secondary brake																																							
PARTNER B9	Active and passive safety	Airbag ECU																																							
BOXER	Engine(6th to 8th digit of VIN)	BMF PUMA	BMF HDI 4C																																						
BOXER	Engine(6th to 8th digit of VIN)	EDC17CP52_UDS 3.0 HDI 180CV E5	EDC17CP52_UDS 3.0 HDI 180CV E5																																						
BOXER	Engine(6th to 8th digit of VIN)	SID208	SID208																																						
BOXER	ABSESP	ESP 90_F																																							
BOXER	ABSESP	ESP 81																																							
BOXER	ABSESP	ABS 81																																							
BOXER	Built-In system interface	Built-In system interface																																							
BOXER	Built-In system interface	Built-In system interface																																							
BOXER	LDWS	LDWS																																							
BIPPER	Engine(6th to 8th digit of VIN)	EDC16C34																																							
BIPPER	Engine(6th to 8th digit of VIN)	HDI_8DF3																																							
BIPPER	Engine(6th to 8th digit of VIN)	BMF PUMA	BMF HDI 4C																																						
BIPPER	Engine(6th to 8th digit of VIN)	EDC17CP52_UDS 3.0 HDI 180CV E5																																							
BIPPER	Engine(6th to 8th digit of VIN)	SID208																																							
BIPPER	ABSESP	ESP 90_F																																							
BIPPER	ABSESP	ESP 81																																							
BIPPER	ABSESP	ABS 81																																							
BIPPER	Built-In system interface	Built-In system interface																																							
BIPPER	Built-In system interface	Built-In system interface																																							
BIPPER	Built-In system interface	Built-In system interface																																							
BIPPER	Airbag	Airbag																																							
BIPPER	LDWS	LDWS																																							
BIPPER	Instrument	Instrument																																							
BIPPER	Parking control	Parking control																																							
EXPERT	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																							
EXPERT	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																							
EXPERT	Engine(6th to 8th digit of VIN)	DCM3.5_BR2																																							
EXPERT	Engine(6th to 8th digit of VIN)	SID807																																							
EXPERT	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																	V						
EXPERT	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																	V						
EXPERT	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																	V						
EXPERT	Engine(6th to 8th digit of VIN)	MED17_4_4																																							
EXPERT	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																							
EXPERT	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																							
EXPERT	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																							
EXPERT	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																							
EXPERT	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																							
EXPERT	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																							

Vehicle	System 1	System 2	System 3	AT Initialising the autoadaptive	Oil wear counter	Alarm Configuration	Personal data zero reset	Telematics screen	Data communication ECU	Data communication ECU - VIN code	Voice mail	Ordinary SMSC number	Emergency voice number for the emergency call	Battery replacement	Radio Configuration	CD changer configuration	Instrument panel Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	Sun roof Configuration	A/C Configuration	TEVES MK20 Bleeding	TEVES MK20 Simulation	Front Left Wheel Solenoid Valve	Front Right Wheel Solenoid Valve	Rear Left Wheel Solenoid Valve	Rear Right Wheel Solenoid Valve	Bleeding	Configuration and display mode	Configuration of options	Remote Control Configuration	Customer language configuration	Configuration of the customer parameter setting menu	Service zero reset	Initialisation of autoadaptatives	Re-centring of autoadaptive systems	Sequence of programming operations(gearbox and clutch actuators)	Gearbox actuator programming operations	Clutch actuator programming operations	Initialisation of the gearbox actuator
EXPERT	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																							
EXPERT	Gearbox ECU	AM6 Euro5 automatic gearbox																																							
EXPERT	Gearbox ECU	AT6 Euro5 automatic gearbox																																							
EXPERT	Gearbox ECU	CFC300P gearbox																																							
EXPERT	Gearbox ECU	AL4 automatic gearbox																																							
EXPERT	Gearbox ECU	BVA_AM6_AT6_UDS																																							
EXPERT	Multiplexed additive adding pump ECU	Multiplexed additive adding pump ECU																																							
EXPERT	ABS or ESP ECU	ESP 81																																							
EXPERT	ABS or ESP ECU	90 ESP																											V												
EXPERT	ABS or ESP ECU	ESP MK 100																																							
EXPERT	Headlamp height adjuster directional headlamp	Headlamp height adjuster/ directional headlamp																																							
EXPERT	Built-In system interface	Built-In system interface																																							
EXPERT	Built-In system interface	Built-In system interface																																							
EXPERT	Power steering electric pump unit	GEP																																							
EXPERT	Power steering electric pump unit	DAE_BVH2																																							
EXPERT	Battery charge status unit	BECB_GEN2																																							
EXPERT	Electric secondary brake	FSE																																							
EXPERT	Engine relay unit	BSM																																							
EXPERT	Trailer relay unit	BSR																																							
EXPERT	Airbag ECU	RBG_UDS																																							
EXPERT	Airbag ECU	RBG_UDS																																							
EXPERT	Airbag ECU	SAC_AUTOLIV																																							
EXPERT	Instrument panel	COMBINE																																							
EXPERT	Instrument panel	COMBINE																																V							
EXPERT	Rain-sunlight sensor	Rain and brightness sensor																																							
EXPERT	Rain-sunlight sensor	CDPL_UDS_HELLA																																							
EXPERT	Switch module at the steering wheel	COM2008P																																							
EXPERT	Switch module at the steering wheel	HDC																																							
EXPERT	Bodywork conversion unit	BTC																																							
EXPERT	Parking aid	AAS																																							
EXPERT	Additional heating	CHAUFF_ADD																																							
EXPERT	Telematics unit	SMEG_PLUS																																							
EXPERT	Anti-theft alarm	ALARME																																							
EXPERT	Rear air conditioning table	TAB_CLIM_AR																																							
EXPERT	Rain and brightness sensor	PLUIE_LUMINOSITE																																							
EXPERT	Supply protection and management unit	BPGA2010																																							
EXPERT	Door control pad	PDPC_UDS																																							
EXPERT	Air conditioning	BCC																																							
EXPERT	Touch screen	Touch screen																																							
EXPERT	Seat belts not fastened LED unit	TNB_2010																																							

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
107	Engine ECU	Petrol engine	ME795																																						
107	Gearbox ECU	MMT																																							
107	Airbag	Airbag																																							
107	ABS or ESP	ABS or ESP																																							
107	Coded anti-start	ADC																																							
107	Power steering	DAE																																							
206	Built-In system interface	Built-In system interface																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	7LZ MM5NP																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	HFX J34P																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D J34P																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFX BOSCH MP7.3																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFX MM1AP																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME7.4.4																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME7.4.4 FLEX FUEL																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW ME749																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW ME749 BIOFLEX																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4 FLEX FUEL																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4 FLEX FUEL																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU or N6A or N6B ME749 BIO FLEX																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU J35																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																						
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM4.8P																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HX/8HZ BOSCH EDC16C3 EURO3																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																																						

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2																																						
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3																																						
206	Engines automatic gearbox	Diesel fuel additive control unit																																							
206	Engines automatic gearbox	AL4 automatic gearbox																																							
206	Engines automatic gearbox	AL4 automatic gearbox																																							
206	Alarm	Alarm																																							
206	Driver informationCommunication	Display/Telematics (AMF)																																							
206	Driver informationCommunication	Display/Telematics (RT3)																																							
206	Driver informationCommunication	Radio																																							
206	Driver informationCommunication	CD Player																																							
206	Driver informationCommunication	Instrument panel																																							
206	Driver informationCommunication	Switching module steering wheel																																							
206	Driver informationCommunication	On-board navigation system																																							
206	VisibilityLighting	Driving school																																							
206	VisibilityLighting	Rain/sunlight sensor																																							
206	Airbag	Airbag SAC Central																																							
206	Control the openings	Electric retractable roof																																							
206	Heatingventilation	A/C																																							
206	Active safety	ABS TEVES MK20																																							
206	Active safety	ABS MK70																																							
206	Active safety	ESP MK60																																							
206	Electric pump unit (power steering)	Power steering																																							
207	Driving assistance Comfort	Parking aid																																							
207	Driving assistance Comfort	Heating/ventilation																																							
207	Driving assistance Comfort	Under inflation detection																																							
207	Driving assistance Comfort	Power steering																																							
207	Built-In system interface	Built-In system interface																																							
207	Inform the driver Audio Communication	Multifunction display																																							
207	Inform the driver Audio Communication	Radio																																							
207	Inform the driver Audio Communication	CD player																																							
207	Inform the driver Audio Communication	Instrument panel																																							
207	Inform the driver Audio Communication	Switch module at the steering wheel																																							
207	Inform the driver Audio Communication	Warning light showing seat belt not fastened																																							
207	Inform the driver Audio Communication	Battery charge status unit																																							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																																						
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6B BOSCH ME7.4.5																																						
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																																						
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FX MED 17.4																																						
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FY MED 17.4																																						

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LPC																																						
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																																						
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4																																						
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV17.4																																						
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FR MEV17.4																																						
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FR MED17.4																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C3																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HL HDI SID807																																						
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HR HDI SID807																																						
207	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox																																						
207	Engine Gearbox	Gearbox ECU	Controlled manual gearbox (BVMP_MA)	V	V																																				
207	Engine Gearbox	Gearbox ECU	CFC300P																																						
207	Vehicle protection Management of accesses	Folding roof																																							
207	Active and passive safety	ABS or ESP ECU																																							
207	Active and passive safety	Airbag ECU				V	V																																		
207	Visibility Lighting Signalling	Rain/sunlight sensor																																							
207	Visibility Lighting Signalling	Static AFS																																							
207	Visibility Lighting Signalling	Switch module at the steering wheel																																							
208	Driving assistance Comfort	Electric power steering																																							
208	Built-In system interface	Built-In system interface						V																																	
208	Inform the driver Audio Communication	Multiplexed control panel																																							
208	Inform the driver Audio Communication	External CD player																																							
208	Inform the driver Audio Communication	Air conditioning																																							
208	Inform the driver Audio Communication	Instrument panel																																							
208	Inform the driver Audio Communication	Switch module at the steering wheel																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HP DV6DTED 92 CV						V	V	V	V	V	V	V	V	V	V	V	V	V																				
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HP DV6DTED 92 CV																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME749_EC5																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																						

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																						
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																						
208	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																						
208	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																						
208	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																						
208	Engine Gearbox	Gearbox ECU	BVA_AL4																																						
208	Active and passive safety	ABS or ESP ECU																																							
208	Active and passive safety	Airbag ECU				V	V																																		
301	Driving assistance Comfort	Power steering																																							
301	Driving assistance Comfort	Parking aid																																							
301	Built-In system interface	Built-In system interface						V																																	
301	Inform the driver Audio Communication	Multifunction display																																							
301	Inform the driver Audio Communication	Radio																																							
301	Inform the driver Audio Communication	Instrument panel																																							
301	Inform the driver Audio Communication	Switch module at the steering wheel																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																						
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																						
301	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																						
301	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																						
301	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																						
301	Engine Gearbox	Gearbox ECU	BVA_AT8																																						
301	Vehicle protection Management of accesses	Driver's door module																																							
301	Active and passive safety	ABS or ESP ECU																																							
301	Active and passive safety	Airbag ECU				V	V																																		
307	Built-in systems interface	Built-in systems interface																				V	V																		
307	Alarm	Alarm																																							

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
307	Driver informationCommunication	Multifunction display																																							
307	Driver informationCommunication	Parking aid																																							
307	Driver informationCommunication	Radio																																							
307	Driver informationCommunication	CD Player																																							
307	Driver informationCommunication	Instrument panel																																							
307	Driver informationCommunication	Switch module at the steering wheel																																							
307	VisibilityLighting	Driving school																																							
307	VisibilityLighting	Rain/sunlight sensor																																							
307	VisibilityLighting	Switch module at the steering wheel																																							
307	Airbag	Airbag ECU																																							
307	Roll-over ECU	Roll-over ECU																																							
307	Control the openings	Driver's door module																																							
307	Control the openings	Passenger's door module																																							
307	Control the openings	Folding roof																																							
307	Heating ventilation	Air conditioning ECU																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM48P (Mechanical throttle housing)																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM4MP2 (Motorised butterfly)																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																						
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHS BOSCH EDC15C2																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHZ BOSCH EDC15C2																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801																																						
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHL SIEMENS SID 803																					V																	
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID 803																					V																	
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3																																						

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
307	Engines automatic gearbox	Diesel fuel additive control unit																																							
307	Engines automatic gearbox	AL4 gearbox																																							
307	Engines automatic gearbox	AL4 gearbox																																							
307	Active safety	ESP BOSCH 5.7																																							
307	Active safety	ABS BOSCH 8																																							
307	Active safety	ESP BOSCH 8																																							
307	Active safety	ABS 81																								V	V														
307	Electric pump unit (power steering)	Power steering																																							
308	Driving assistance Comfort	Heating/ventilation																																							
308	Driving assistance Comfort	Power steering																																							
308	Driving assistance Comfort	Parking aid																																							
308	Built-In system interface	Built-In system interface																																							
308	Inform the driver Audio Communication	Multifunction display																																							
308	Inform the driver Audio Communication	Radio																																							
308	Inform the driver Audio Communication	Instrument panel																																							
308	Inform the driver Audio Communication	Warning light showing seat belt not fastened																																							
308	Inform the driver Audio Communication	Switch module at the steering wheel																																							
308	Inform the driver Audio Communication	Battery charge status unit																																							
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																																						
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4																																						
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX EDC16C3																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY EDC16C3																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4																																						
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4																																						
308	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																						
308	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																						
308	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																						
308	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox																																						
308	Engine Gearbox	Multiplexed additive adding pump ECU																																							
308	Vehicle protection Management of accesses	Driver's door module																																							
308	Active and passive safety	ABS or ESP ECU																																							
308	Active and passive safety	Airbag ECU																																							
308	Visibility Lighting Signalling	Rain/sunlight sensor																																							
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																																						
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4																																						
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																						

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Aditive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	MED17_4_4																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	EDC17C10_BR2						V	V	V	V	V	V	V	V	V	V	V	V	V																				
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	EDC17C10_BR2																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	SID807																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	DCM3.5_BR2						V																	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX EDC16C3																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY EDC16C3																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4																																						
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4																																						
308(T9)	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																						
308(T9)	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																						
308(T9)	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																						
308(T9)	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox																																						
308(T9)	Engine Gearbox	Gearbox ECU	BVA_AM6_AT6_UDS																																						
308(T9)	Engine Gearbox	Multiplexed additive adding pump ECU																																							
308(T9)	Headlamp height adjuster directional headlamp	LADCT																																							
308(T9)	Built-In system interface	Built-In system interface						V																																	
308(T9)	Switch module at the steering wheel	COM2008P																																							
308(T9)	ABS or ESP ECU	90 ESP																							V																
308(T9)	ABS or ESP ECU	ESP 81																							V	V															
308(T9)	ABS or ESP ECU	ESP MK 100																																							
308(T9)	Airbag ECU	RBG_UDS																																							
308(T9)	Engine relay unit	Engine relay unit																																							
308(T9)	Supply protection and management unit	BPGA2010																																							
308(T9)	Door control pad	PDPC_UDS																																							
308(T9)	Electric power steering	DAE_BVH2																																							
308(T9)	Telematics unit SMEG_PLUS	SMEG_PLUS																																							
308(T9)	Air conditioning	BCC																																							
308(T9)	Controls on the steering wheel	Controls on the steering wheel																																							
308(T9)	Touch screen	Touch screen																																							
308(T9)	Rain-sunlight sensor	CDPL_UDS_HELLA																																							
308(T9)	Seat belts not fastened LED unit	TNB_2010																																							
405	Engine(6th to 8th digit of VIN)	L6A SAGEM SL96																																							
405	Engine(6th to 8th digit of VIN)	1600RD SL96																																							
405	Engine(6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																																							
405	Engine(6th to 8th digit of VIN)	N6B BOSCH ME7.4.4																																							
405	Engine(6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																							

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Aditive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
405	Engine(6th to 8th digit of VIN)	LFZ SAGEM S2000																																							
405	Engine(6th to 8th digit of VIN)	LFZ SAGEM S2000																																							
405	Engine(6th to 8th digit of VIN)	1600RD SAGEM S2000																																							
405	Engine(6th to 8th digit of VIN)	1600RD SAGEM S2000																																							
405	Engine(6th to 8th digit of VIN)	LFY BOSCH MP7.3																																							
405	Engine(6th to 8th digit of VIN)	NFU J35																																							
406	Built-in systems interface	Built-in systems interface																				V	V																		
406	Alarm	Alarm																																							
406	Driver informationCommunication	Multifunction display																																							
406	Driver informationCommunication	Instrument panel																																							
406	Driver informationCommunication	Radio																																							
406	Driver informationCommunication	CD Player																																							
406	Driver informationCommunication	On-board navigation system																																							
406	VisibilityLighting	Rain/sunlight sensor																																							
406	Airbag	Airbag ECU				V	V																																		
406	Heating ventilation	Air conditioning ECU																																							
406	Active safety	ABS BOSCH 5.3																																							
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	3FZ MM4MP2																																						
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	6FZ SAGEM S2000																																						
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	6FZ SAGEM S2000																																						
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	R6F MM 4.8P																																						
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM 4.8P																																						
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	XFX BOSCH ME 7.4.6																																						
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	4HX BOSCH EDC15C2																																						
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHS BOSCH EDC15C2																																						
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																						
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHZ BOSCH EDC15C2																																						
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801																																						
406	Engines automatic gearbox	Diesel fuel additive control unit																																							
406	Engines automatic gearbox	Automatic gearbox																																							
406	Engines automatic gearbox	Automatic gearbox																																							
407	Driving assistance Comfort	Parking aid																																							
407	Driving assistance Comfort	Heating/ventilation																																							
407	Driving assistance Comfort	Under inflation detection																																							
407	Driving assistance Comfort	Power steering																																							
407	Built-In system interface	Built-In system interface																																							
407	Inform the driver Audio Communication	Multifunction display	TYPE 'C'(DOT MATRIX)																																						
407	Inform the driver Audio Communication	Multifunction display	TYPE 'C COLOUR'(DOT MATRIX)																																						
407	Inform the driver Audio Communication	Radio																																							
407	Inform the driver Audio Communication	CD player																																							

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
407	Inform the driver Audio Communication	Instrument panel																																							
407	Inform the driver Audio Communication	Switch module at the steering wheel																																							
407	Inform the driver Audio Communication	Telematics																																							
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	XFV ME747																																						
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	3FZ MM6LP																																						
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL SIEMENS SID 803																					V																	
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID 803																					V																	
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	UHZ SID 201						V	V			V					V																							
407	Engine Gearbox	Diesel fuel additive control unit																																							
407	Engine Gearbox	Gearbox ECU	AM6 automatic gearbox																																						
407	Engine Gearbox	Gearbox ECU	BVA_AL4_AT8																																						
407	Engine Gearbox	Gearbox ECU	BVA_AL4_AT8																																						
407	Vehicle protection Management of accesses	Driver's door module																																							
407	Vehicle protection Management of accesses	Passenger's door module																																							
407	Vehicle protection Management of accesses	Sun roof																																							
407	Active and passive safety	ABS or ESP ECU																																							
407	Active and passive safety	ABS or ESP ECU																							V																
407	Active and passive safety	Airbag ECU																																							
407	Visibility Lighting Signalling	Control unit Windscreen wipers																																							
407	Visibility Lighting Signalling	Rain/sunlight sensor																																							
3008	Driving assistance Comfort	High Head Vision																																							
3008	Driving assistance Comfort	Assistance in complying with the inter-vehicle time (ARTIV)																																							
3008	Driving assistance Comfort	Air conditioning ECU																																							
3008	Driving assistance Comfort	Parking aid																																							
3008	Driving assistance Comfort	Electropump assembly																																							
3008	Driving assistance Comfort	Under inflation detection																																							
3008	Driving assistance Comfort	Electric parking brake																																							
3008	Built-In system interface	Built-In system interface																																							
3008	Inform the driver Audio Communication	Multifunction display (EMF)																																							
3008	Inform the driver Audio Communication	Switch module at the steering wheel																																							
3008	Inform the driver Audio Communication	Radio																																							
3008	Inform the driver Audio Communication	Instrument panel																																							
3008	Inform the driver Audio Communication	Control panel dot matrix display																																							
3008	Inform the driver Audio Communication	Battery charge status unit																																							
3008	Inform the driver Audio Communication	Not Fastened warning light (TNB)																																							

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																																						
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4																																						
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FX MED 17.4																																						
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FV MED 17.4																																						
3008	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3																																						
3008	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HD HDI_SID807_BR2																																						
3008	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																						
3008	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																						
3008	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																						
3008	Engine Gearbox	Multiplexed additive adding pump ECU																																							
3008	Vehicle protection Management of accesses	Driver's door module																																							
3008	Active and passive safety	ABS or ESP ECU																							V																
3008	Active and passive safety	Airbag ECU																																							
3008	Visibility Lighting Signalling	Rain sensor																																							
3008	Visibility Lighting Signalling	Windscreen wiper																																							
5008	Driving assistance Comfort	Power steering																																							
5008	Driving assistance Comfort	Parking aid																																							
5008	Built-In system interface	Built-In system interface																																							
5008	Inform the driver Audio Communication	Multifunction display																																							
5008	Inform the driver Audio Communication	Radio																																							
5008	Inform the driver Audio Communication	Instrument panel																																							
5008	Inform the driver Audio Communication	Switch module at the steering wheel																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HR HDI SID807																																						
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR SIEMENS SID803A						V									V																							
5008	Engine Gearbox	Gearbox ECU	Auto gearbox AL4																																						
5008	Engine Gearbox	Gearbox ECU	AM6 Euro5																																						
5008	Engine Gearbox	Gearbox ECU	AT6 Euro5																																						
5008	Engine Gearbox	Gearbox ECU	CFC300P																																						
5008	Engine Gearbox	Gearbox ECU	BVA_AT8																																						
5008	Vehicle protection Management of accesses	Engine relay unit																																							

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
5008	Vehicle protection Management of accesses	Trailer relay unit																																							
5008	Vehicle protection Management of accesses	Windscreen wiper																																							
5008	Active and passive safety	ABS or ESP ECU																																							
5008	Active and passive safety	Electric secondary brake																																							
5008	Active and passive safety	Airbag ECU			V	V																																			
PARTNER	Driving assistance Comfort	Parking aid																																							
PARTNER	Built-In system interface	Built-In system interface																				V	V																		
PARTNER	Driver information Communication	Display / Telematics																																							
PARTNER	Driver information Communication	Radio																																							
PARTNER	Driver information Communication	CD Player																																							
PARTNER	Driver information Communication	Instrument panel																																							
PARTNER	Driver information Communication	Switching module below steering wheel (COM 2000)																																							
PARTNER	Airbags	Airbags			V	V																																			
PARTNER	VisibilityLighting	Switching module below steering wheel (COM 2000)																																							
PARTNER	VisibilityLighting	Rain/sunlight sensor																																							
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6B BOSCH ME7.4.5																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU or N6A BOSCH ME749																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749 BIO FLEX																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME749																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME749 BIO FLEX																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID801																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HW BOSCH EDC16C3																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																						
PARTNER	Active Safety	ESP BOSCH 5.7																																							
PARTNER	Active Safety	ABS BOSCH 8																																							
PARTNER	Active Safety	ESP BOSCH 8																																							
PARTNER	Active Safety	ABS 8.1																																							

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
PARTNER	Active Safety	ESP 8.1																																							
PARTNER B9	Driving assistance Comfort	Power steering																																							
PARTNER B9	Driving assistance Comfort	Parking aid																																							
PARTNER B9	Built-In system interface	Built-In system interface																																							
PARTNER B9	Inform the driver Audio Communication	Multifunction display																																							
PARTNER B9	Inform the driver Audio Communication	Bodywork conversion unit																																							
PARTNER B9	Inform the driver Audio Communication	Instrument panel																																							
PARTNER B9	Inform the driver Audio Communication	Switch module at the steering wheel																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HF-DV6DTED-89 CV						V	V	V	V	V	V	V	V	V	V	V	V	V																				
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HF-DV6DTED-89 CV																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HE-DV6DTED-89 CV						V	V	V	V	V	V	V	V	V	V	V	V	V																				
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HE-DV6DTED-89 CV																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	HDI_SID807_BR2 HDI_SID807_BR2 9HL																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 NFU																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 N6B																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 N6A																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 NFR																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HR HDI SID807																																						
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR SIEMENS SID803A						V										V																						
PARTNER B9	Engine Gearbox	Gearbox ECU	Auto gearbox AL4																																						
PARTNER B9	Engine Gearbox	Gearbox ECU	AM6 Euro5																																						
PARTNER B9	Engine Gearbox	Gearbox ECU	AT6 Euro5																																						
PARTNER B9	Engine Gearbox	Gearbox ECU	CFC300P																																						
PARTNER B9	Engine Gearbox	Gearbox ECU	BVA_AT8																																						
PARTNER B9	Vehicle protection Management of accesses	Engine relay unit																																							
PARTNER B9	Vehicle protection Management of accesses	Trailer relay unit																																							
PARTNER B9	Vehicle protection Management of accesses	Windscreen wiper																																							
PARTNER B9	Active and passive safety	ABS or ESP ECU	ESP 81																						V	V															
PARTNER B9	Active and passive safety	ABS or ESP ECU	ESP MK 100																																						
PARTNER B9	Active and passive safety	ABS or ESP ECU	90 ESP																						V																

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Additive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
PARTNER B9	Active and passive safety	Electric secondary brake																																							
PARTNER B9	Active and passive safety	Airbag ECU				V	V																																		
BOXER	Engine(6th to 8th digit of VIN)	BMF PUMA	BMF HDI 4C																																						
BOXER	Engine(6th to 8th digit of VIN)	EDC17CP52_UDS 3.0 HDI 180CV E5	EDC17CP52_UDS 3.0 HDI 180CV E5																V																						
BOXER	Engine(6th to 8th digit of VIN)	SID208	SID208																V																						
BOXER	ABSESP	ESP 90_F																							V																
BOXER	ABSESP	ESP 81																							V																
BOXER	ABSESP	ABS 81																																							
BOXER	Built-In system interface	Built-In system interface																																							
BOXER	Built-In system interface	Built-In system interface																																							
BOXER	LDWS	LDWS																																							
BIPPER	Engine(6th to 8th digit of VIN)	EDC16C34																																							
BIPPER	Engine(6th to 8th digit of VIN)	HDI_8DF3																																							
BIPPER	Engine(6th to 8th digit of VIN)	BMF PUMA	BMF HDI 4C																																						
BIPPER	Engine(6th to 8th digit of VIN)	EDC17CP52_UDS 3.0 HDI 180CV E5																	V																						
BIPPER	Engine(6th to 8th digit of VIN)	SID208																	V																						
BIPPER	ABSESP	ESP 90_F																							V																
BIPPER	ABSESP	ESP 81																							V																
BIPPER	ABSESP	ABS 81																																							
BIPPER	Built-In system interface	Built-In system interface																																							
BIPPER	Built-In system interface	Built-In system interface																																							
BIPPER	Built-In system interface	Built-In system interface																																							
BIPPER	Airbag	Airbag																																							
BIPPER	LDWS	LDWS																																							
BIPPER	Instrument	Instrument																																							
BIPPER	Parking control	Parking control																																							
EXPERT	Engine(6th to 8th digit of VIN)	EDC17C10_BR2							V	V	V	V	V	V	V	V	V	V	V	V	V																				
EXPERT	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																							
EXPERT	Engine(6th to 8th digit of VIN)	DCM3.5_BR2							V																		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
EXPERT	Engine(6th to 8th digit of VIN)	SID807																																							
EXPERT	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																							
EXPERT	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																							
EXPERT	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																							
EXPERT	Engine(6th to 8th digit of VIN)	MED17_4_4																																							
EXPERT	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																							
EXPERT	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																							
EXPERT	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																							
EXPERT	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																							
EXPERT	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																							
EXPERT	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																							

Vehicle	System 1	System 2	System 3	Setting of the gearbox actuator to the removal position	Setting of the gearbox actuator to the fitting position	Locking	Unlocking	Reset to zero of the counter for the number of restarts	Forced Regeneration Of The Particle Filter Vehicle Stationary	Change of EGR Valve	Replacement Of The EGR Exchanger	Change Of Air Mixer	Replacement Of The Turbo	Replacement Of The Aditive Reservoir Of Pump Or Pipes	Replacement Of The High Pressure Pump Or Regulation Valve	Replacement Of The Exhaust Manifold	Replacement Of Tthe Cylinder Head	Replacement Of The Diesel High Pressure Rail	Replacement Of The Particle Emission Filter	Filling Of The Diesel Additive Tank	Replacement Of The Oxygen Sensor	Programming of the Confidential Code of the BSI	Programming of keys	Fuel additive level zero reset(BETA)	Calibration of the steering wheel angle sensor	Air Bleeding	Filling of the diesel additive adding reservoir	Replacement of the diesel additive reservoir+ pump/pipes	Replacement of the particle emission filter	Change of EGR valve	Replacement of the EGR exchanger	Replacement of the turbo	Air flow sensor replacement	Replacement of the differential pressure sensor	Replacement of the high pressure pump or the flow regulation valve	Replacement of the diesel high pressure rail	Replacement of the additive reservoir+ pump or pipes	Filling of the diesel additive tank	Change of air mixer	Replacement of the oxygen sensor	Change of engine block without the flowmeter
EXPERT	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																							
EXPERT	Gearbox ECU	AM6 Euro5 automatic gearbox																																							
EXPERT	Gearbox ECU	AT6 Euro5 automatic gearbox																																							
EXPERT	Gearbox ECU	CFC300P gearbox																																							
EXPERT	Gearbox ECU	AL4 automatic gearbox																																							
EXPERT	Gearbox ECU	BVA_AM6_AT6_UDS																																							
EXPERT	Multiplexed additive adding pump ECU	Multiplexed additive adding pump ECU																																							
EXPERT	ABS or ESP ECU	ESP 81																																							
EXPERT	ABS or ESP ECU	90 ESP																							V																
EXPERT	ABS or ESP ECU	ESP MK 100																																							
EXPERT	Headlamp height adjuster directional headlamp	Headlamp height adjuster/ directional headlamp																																							
EXPERT	Built-In system interface	Built-In system interface						V																																	
EXPERT	Built-In system interface	Built-In system interface																																							
EXPERT	Power steering electric pump unit	GEP																																							
EXPERT	Power steering electric pump unit	DAE_BVH2																																							
EXPERT	Battery charge status unit	BECB_GEN2																																							
EXPERT	Electric secondary brake	FSE																																							
EXPERT	Engine relay unit	BSM																																							
EXPERT	Trailer relay unit	BSR																																							
EXPERT	Airbag ECU	RBG_UDS				V	V																																		
EXPERT	Airbag ECU	RBG_UDS																																							
EXPERT	Airbag ECU	SAC_AUTOLIV				V	V																																		
EXPERT	Instrument panel	COMBINE																																							
EXPERT	Instrument panel	COMBINE																																							
EXPERT	Rain-sunlight sensor	Rain and brightness sensor																																							
EXPERT	Rain-sunlight sensor	CDPL_UDS_HELLA																																							
EXPERT	Switch module at the steering wheel	COM2008P																																							
EXPERT	Switch module at the steering wheel	HDC																																							
EXPERT	Bodywork conversion unit	BTC																																							
EXPERT	Parking aid	AAS																																							
EXPERT	Additional heating	CHAUFF_ADD																																							
EXPERT	Telematics unit	SMEG_PLUS																																							
EXPERT	Anti-theft alarm	ALARME																																							
EXPERT	Rear air conditioning table	TAB_CLIM_AR																																							
EXPERT	Rain and brightness sensor	PLUIE_LUMINOSITE																																							
EXPERT	Supply protection and management unit	BPGA2010																																							
EXPERT	Door control pad	PDPC_UDS																																							
EXPERT	Air conditioning	BCC																																							
EXPERT	Touch screen	Touch screen																																							
EXPERT	Seat belts not fastened LED unit	TNB_2010																																							

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Or Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
107	Engine ECU	Petrol engine	ME795																																							
107	Gearbox ECU	MMT																																								
107	Airbag	Airbag																																								
107	ABS or ESP	ABS or ESP																																								
107	Coded anti-start	ADC																																								
107	Power steering	DAE																																								
206	Built-In system interface	Built-In system interface																																								
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	7LZ MM5NP																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	HFX J34P																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D J34P																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFX BOSCH MP7.3																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFX MM1AP																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME7.4.4																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME7.4.4 FLEX FUEL																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW ME749																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW ME749 BIOFLEX																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4 FLEX FUEL																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4 FLEX FUEL																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU or N6A or N6B ME749 BIO FLEX																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU J35																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																							
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM4.8P																																							
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HX/8HZ BOSCH EDC16C3 EURO3																																							
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4																																							
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4																																							
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																																							
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																																							
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																																							

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																							
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2																																							
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3																																							
206	Engines automatic gearbox	Diesel fuel additive control unit																																								
206	Engines automatic gearbox	AL4 automatic gearbox																																								
206	Engines automatic gearbox	AL4 automatic gearbox																																								
206	Alarm	Alarm																																								
206	Driver informationCommunication	Display/Telematics (AMF)																																								
206	Driver informationCommunication	Display/Telematics (RT3)																																								
206	Driver informationCommunication	Radio																																								
206	Driver informationCommunication	CD Player																																								
206	Driver informationCommunication	Instrument panel																																								
206	Driver informationCommunication	Switching module steering wheel																																								
206	Driver informationCommunication	On-board navigation system																																								
206	VisibilityLighting	Driving school																																								
206	VisibilityLighting	Rain/sunlight sensor																																								
206	Airbag	Airbag SAC Central																																								
206	Control the openings	Electric retractable roof																																								
206	Heatingventilation	A/C																																								
206	Active safety	ABS TEVES MK20																																								
206	Active safety	ABS MK70																																								
206	Active safety	ESP MK60																																								
206	Electric pump unit (power steering)	Power steering																																								
207	Driving assistance Comfort	Parking aid																																								
207	Driving assistance Comfort	Heating/ventilation																																								
207	Driving assistance Comfort	Under inflation detection																																								
207	Driving assistance Comfort	Power steering																																								
207	Built-In system interface	Built-In system interface																																								
207	Inform the driver Audio Communication	Multifunction display																																								
207	Inform the driver Audio Communication	Radio																																								
207	Inform the driver Audio Communication	CD player																																								
207	Inform the driver Audio Communication	Instrument panel																																								
207	Inform the driver Audio Communication	Switch module at the steering wheel																																								
207	Inform the driver Audio Communication	Warning light showing seat belt not fastened																																								
207	Inform the driver Audio Communication	Battery charge status unit																																								
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																																							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6B BOSCH ME7.4.5																																							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																																							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FX MED 17.4																																							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FY MED 17.4																																							

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LPC																																							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																																							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4																																							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV17.4																																							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FR MEV17.4																																							
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FR MED17.4																																							
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4																																							
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																																							
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4																																							
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																																							
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C3																																							
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																																							
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3																																							
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HL HDI SID807																																							
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HR HDI SID807																																							
207	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox																																							
207	Engine Gearbox	Gearbox ECU	Controlled manual gearbox (BVMP_MA)																																							
207	Engine Gearbox	Gearbox ECU	CFC300P																																							
207	Vehicle protection Management of accesses	Folding roof																																								
207	Active and passive safety	ABS or ESP ECU																																								
207	Active and passive safety	Airbag ECU																																								
207	Visibility Lighting Signalling	Rain/sunlight sensor																																								
207	Visibility Lighting Signalling	Static AFS																																								
207	Visibility Lighting Signalling	Switch module at the steering wheel																																								
208	Driving assistance Comfort	Electric power steering																																								
208	Built-In system interface	Built-In system interface																																								
208	Inform the driver Audio Communication	Multiplexed control panel																																								
208	Inform the driver Audio Communication	External CD player																																								
208	Inform the driver Audio Communication	Air conditioning																																								
208	Inform the driver Audio Communication	Instrument panel																																								
208	Inform the driver Audio Communication	Switch module at the steering wheel																																								
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HP DV6DTED 92 CV																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HP DV6DTED 92 CV																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME749_EC5																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																							

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Or Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																							
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																							
208	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																							
208	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																							
208	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																							
208	Engine Gearbox	Gearbox ECU	BVA_AL4																																							
208	Active and passive safety	ABS or ESP ECU																																								
208	Active and passive safety	Airbag ECU																																								
301	Driving assistance Comfort	Power steering																																								
301	Driving assistance Comfort	Parking aid																																								
301	Built-In system interface	Built-In system interface																																								
301	Inform the driver Audio Communication	Multifunction display																																								
301	Inform the driver Audio Communication	Radio																																								
301	Inform the driver Audio Communication	Instrument panel																																								
301	Inform the driver Audio Communication	Switch module at the steering wheel																																								
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																							
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																							
301	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																							
301	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																							
301	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																							
301	Engine Gearbox	Gearbox ECU	BVA_AT8																																							
301	Vehicle protection Management of accesses	Driver's door module																																								
301	Active and passive safety	ABS or ESP ECU																																								
301	Active and passive safety	Airbag ECU																																								
307	Built-in systems interface	Built-in systems interface																																								
307	Alarm	Alarm																																								

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Or Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
307	Driver informationCommunication	Multifunction display																																								
307	Driver informationCommunication	Parking aid																																								
307	Driver informationCommunication	Radio																																								
307	Driver informationCommunication	CD Player																																								
307	Driver informationCommunication	Instrument panel																																								
307	Driver informationCommunication	Switch module at the steering wheel																																								
307	VisibilityLighting	Driving school																																								
307	VisibilityLighting	Rain/sunlight sensor																																								
307	VisibilityLighting	Switch module at the steering wheel																																								
307	Airbag	Airbag ECU																																								
307	Roll-over ECU	Roll-over ECU																																								
307	Control the openings	Driver's door module																																								
307	Control the openings	Passenger's door module																																								
307	Control the openings	Folding roof																																								
307	Heating ventilation	Air conditioning ECU																																								
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM48P (Mechanical throttle housing)																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM4MP2 (Motorised butterfly)																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LP																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFK MM6LP																																							
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																							
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3																																							
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																																							
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4																																							
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																																							
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																																							
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHS BOSCH EDC15C2																																							
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																							
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHZ BOSCH EDC15C2																																							
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801																																							
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHL SIEMENS SID 803																																							
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID 803																																							
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3																																							

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Or Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
307	Engines automatic gearbox	Diesel fuel additive control unit																																								
307	Engines automatic gearbox	AL4 gearbox																																								
307	Engines automatic gearbox	AL4 gearbox																																								
307	Active safety	ESP BOSCH 5.7																																								
307	Active safety	ABS BOSCH 8																																								
307	Active safety	ESP BOSCH 8																																								
307	Active safety	ABS 81																																								
307	Electric pump unit (power steering)	Power steering																																								
308	Driving assistance Comfort	Heating/ventilation																																								
308	Driving assistance Comfort	Power steering																																								
308	Driving assistance Comfort	Parking aid																																								
308	Built-In system interface	Built-In system interface																																								
308	Inform the driver Audio Communication	Multifunction display																																								
308	Inform the driver Audio Communication	Radio																																								
308	Inform the driver Audio Communication	Instrument panel																																								
308	Inform the driver Audio Communication	Warning light showing seat belt not fastened																																								
308	Inform the driver Audio Communication	Switch module at the steering wheel																																								
308	Inform the driver Audio Communication	Battery charge status unit																																								
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																																							
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4																																							
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																							
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX EDC16C3																																							
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY EDC16C3																																							
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3																																							
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3																																							
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4																																							
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4																																							
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4																																							
308	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																							
308	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																							
308	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																							
308	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox																																							
308	Engine Gearbox	Multiplexed additive adding pump ECU																																								
308	Vehicle protection Management of accesses	Driver's door module																																								
308	Active and passive safety	ABS or ESP ECU																																								
308	Active and passive safety	Airbag ECU																																								
308	Visibility Lighting Signalling	Rain/sunlight sensor																																								
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																																							
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4																																							
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																							

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	MED17_4_4																																							
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	EDC17C10_BR2																																							
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	EDC17C10_BR2																																							
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	SID807																																							
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	DCM3.5_BR2	V	V	V	V																																			
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX EDC16C3																																							
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY EDC16C3																																							
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3																																							
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3																																							
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4																																							
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4																																							
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4																																							
308(T9)	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																							
308(T9)	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																							
308(T9)	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																							
308(T9)	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox																																							
308(T9)	Engine Gearbox	Gearbox ECU	BVA_AM6_AT6_UDS																																							
308(T9)	Engine Gearbox	Multiplexed additive adding pump ECU																																								
308(T9)	Headlamp height adjuster directional headlamp	LADCT																																								
308(T9)	Built-In system interface	Built-In system interface																																								
308(T9)	Switch module at the steering wheel	COM2008P																																								
308(T9)	ABS or ESP ECU	90 ESP						V	V	V	V	V	V	V	V	V	V																									
308(T9)	ABS or ESP ECU	ESP 81																																								
308(T9)	ABS or ESP ECU	ESP MK 100																V	V	V																						
308(T9)	Airbag ECU	RBG_UDS																																								
308(T9)	Engine relay unit	Engine relay unit																																								
308(T9)	Supply protection and management unit	BPGA2010																																								
308(T9)	Door control pad	PDPC_UDS																																								
308(T9)	Electric power steering	DAE_BVH2																																								
308(T9)	Telematics unit SMEG_PLUS	SMEG_PLUS																																								
308(T9)	Air conditioning	BCC																																								
308(T9)	Controls on the steering wheel	Controls on the steering wheel																																								
308(T9)	Touch screen	Touch screen																																								
308(T9)	Rain-sunlight sensor	CDPL_UDS_HELLA																			V																					
308(T9)	Seat belts not fastened LED unit	TNB_2010																																								
405	Engine(6th to 8th digit of VIN)	L6A SAGEM SL96																																								
405	Engine(6th to 8th digit of VIN)	1600RD SL96																																								
405	Engine(6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																																								
405	Engine(6th to 8th digit of VIN)	N6B BOSCH ME7.4.4																																								
405	Engine(6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																								

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Or Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
405	Engine(6th to 8th digit of VIN)	LFZ SAGEM S2000																																								
405	Engine(6th to 8th digit of VIN)	LFZ SAGEM S2000																																								
405	Engine(6th to 8th digit of VIN)	1600RD SAGEM S2000																																								
405	Engine(6th to 8th digit of VIN)	1600RD SAGEM S2000																																								
405	Engine(6th to 8th digit of VIN)	LFY BOSCH MP7.3																																								
405	Engine(6th to 8th digit of VIN)	NFU J35																																								
406	Built-in systems interface	Built-in systems interface																				V																				
406	Alarm	Alarm																																								
406	Driver informationCommunication	Multifunction display																																								
406	Driver informationCommunication	Instrument panel																																								
406	Driver informationCommunication	Radio																																								
406	Driver informationCommunication	CD Player																																								
406	Driver informationCommunication	On-board navigation system																																								
406	VisibilityLighting	Rain/sunlight sensor																																								
406	Airbag	Airbag ECU																																								
406	Heating ventilation	Air conditioning ECU																																								
406	Active safety	ABS BOSCH 5.3																																								
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	3FZ MM4MP2																																							
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	6FZ SAGEM S2000																																							
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	6FZ SAGEM S2000																																							
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	R6F MM 4.8P																																							
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM 4.8P																																							
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	XFX BOSCH ME 7.4.6																																							
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	4HX BOSCH EDC15C2																																							
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHS BOSCH EDC15C2																																							
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																							
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHZ BOSCH EDC15C2																																							
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801																																							
406	Engines automatic gearbox	Diesel fuel additive control unit																																								
406	Engines automatic gearbox	Automatic gearbox																																								
406	Engines automatic gearbox	Automatic gearbox																																								
407	Driving assistance Comfort	Parking aid																																								
407	Driving assistance Comfort	Heating/ventilation																																								
407	Driving assistance Comfort	Under inflation detection																																								
407	Driving assistance Comfort	Power steering																																								
407	Built-In system interface	Built-In system interface																																								
407	Inform the driver Audio Communication	Multifunction display	TYPE 'C'(DOT MATRIX)																																							
407	Inform the driver Audio Communication	Multifunction display	TYPE 'C COLOUR'(DOT MATRIX)																				V	V	V																	
407	Inform the driver Audio Communication	Radio																																								
407	Inform the driver Audio Communication	CD player																																								

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Or Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
407	Inform the driver Audio Communication	Instrument panel																																							
407	Inform the driver Audio Communication	Switch module at the steering wheel																																							
407	Inform the driver Audio Communication	Telematics																																							
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	XFV ME747																																						
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	3FZ MM6LP																																						
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL SIEMENS SID 803																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID 803																																						
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	UHZ SID 201																							V	V	V													
407	Engine Gearbox	Diesel fuel additive control unit																																							
407	Engine Gearbox	Gearbox ECU	AM6 automatic gearbox																																						
407	Engine Gearbox	Gearbox ECU	BVA_AL4_AT8																																						
407	Engine Gearbox	Gearbox ECU	BVA_AL4_AT8																																						
407	Vehicle protection Management of accesses	Driver's door module																																							
407	Vehicle protection Management of accesses	Passenger's door module																																							
407	Vehicle protection Management of accesses	Sun roof																																							
407	Active and passive safety	ABS or ESP ECU																											V												
407	Active and passive safety	ABS or ESP ECU																																							
407	Active and passive safety	Airbag ECU																																							
407	Visibility Lighting Signalling	Control unit Windscreen wipers																																							
407	Visibility Lighting Signalling	Rain/sunlight sensor																																							
3008	Driving assistance Comfort	High Head Vision																																							
3008	Driving assistance Comfort	Assistance in complying with the inter-vehicle time (ARTIV)																																							
3008	Driving assistance Comfort	Air conditioning ECU																																							
3008	Driving assistance Comfort	Parking aid																																							
3008	Driving assistance Comfort	Electropump assembly																																							
3008	Driving assistance Comfort	Under inflation detection																																							
3008	Driving assistance Comfort	Electric parking brake																												V	V										
3008	Built-In system interface	Built-In system interface																																							
3008	Inform the driver Audio Communication	Multifunction display (EMF)																																							
3008	Inform the driver Audio Communication	Switch module at the steering wheel																																							
3008	Inform the driver Audio Communication	Radio																																							
3008	Inform the driver Audio Communication	Instrument panel																																							
3008	Inform the driver Audio Communication	Control panel dot matrix display																																							
3008	Inform the driver Audio Communication	Battery charge status unit																																							
3008	Inform the driver Audio Communication	Not Fastened warning light (TNB)																																							

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Or Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																																							
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4																																							
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FX MED 17.4																																							
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FV MED 17.4																																							
3008	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3																																							
3008	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HD HDI_SID807_BR2																																							
3008	Engine Gearbox	Gearbox ECU	CFC300P gearbox																																							
3008	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																																							
3008	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																																							
3008	Engine Gearbox	Multiplexed additive adding pump ECU																																								
3008	Vehicle protection Management of accesses	Driver's door module																																								
3008	Active and passive safety	ABS or ESP ECU																																								
3008	Active and passive safety	Airbag ECU																																								
3008	Visibility Lighting Signalling	Rain sensor																																								
3008	Visibility Lighting Signalling	Windscreen wiper																																								
5008	Driving assistance Comfort	Power steering																																								
5008	Driving assistance Comfort	Parking aid																																								
5008	Built-In system interface	Built-In system interface																																								
5008	Inform the driver Audio Communication	Multifunction display																																								
5008	Inform the driver Audio Communication	Radio																																								
5008	Inform the driver Audio Communication	Instrument panel																																								
5008	Inform the driver Audio Communication	Switch module at the steering wheel																																								
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HR HDI SID807																																							
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR SIEMENS SID803A																													V	V									
5008	Engine Gearbox	Gearbox ECU	Auto gearbox AL4																																							
5008	Engine Gearbox	Gearbox ECU	AM6 Euro5																																							
5008	Engine Gearbox	Gearbox ECU	AT6 Euro5																																							
5008	Engine Gearbox	Gearbox ECU	CFC300P																																							
5008	Engine Gearbox	Gearbox ECU	BVA_AT8																																							
5008	Vehicle protection Management of accesses	Engine relay unit																																								

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Or Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
5008	Vehicle protection Management of accesses	Trailer relay unit																																							
5008	Vehicle protection Management of accesses	Windscreen wiper																																							
5008	Active and passive safety	ABS or ESP ECU																																							
5008	Active and passive safety	Electric secondary brake																												V	V										
5008	Active and passive safety	Airbag ECU																																							
PARTNER	Driving assistance Comfort	Parking aid																																							
PARTNER	Built-In system interface	Built-In system interface																																							
PARTNER	Driver information Communication	Display / Telematics																																							
PARTNER	Driver information Communication	Radio																																							
PARTNER	Driver information Communication	CD Player																																							
PARTNER	Driver information Communication	Instrument panel																																							
PARTNER	Driver information Communication	Switching module below steering wheel (COM 2000)																																							
PARTNER	Airbags	Airbags																																							
PARTNER	VisibilityLighting	Switching module below steering wheel (COM 2000)																																							
PARTNER	VisibilityLighting	Rain/sunlight sensor																																							
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6B BOSCH ME7.4.5																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU or N6A BOSCH ME749																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749 BIO FLEX																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME749																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME749 BIO FLEX																																						
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID801																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HW BOSCH EDC16C3																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																																						
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																																						
PARTNER	Active Safety	ESP BOSCH 5.7																																							
PARTNER	Active Safety	ABS BOSCH 8																																							
PARTNER	Active Safety	ESP BOSCH 8																																							
PARTNER	Active Safety	ABS 8.1																																							

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Of Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
PARTNER	Active Safety	ESP 8.1																																								
PARTNER B9	Driving assistance Comfort	Power steering																																								
PARTNER B9	Driving assistance Comfort	Parking aid																																								
PARTNER B9	Built-In system interface	Built-In system interface																																								
PARTNER B9	Inform the driver Audio Communication	Multifunction display																																								
PARTNER B9	Inform the driver Audio Communication	Bodywork conversion unit																																								
PARTNER B9	Inform the driver Audio Communication	Instrument panel																																								
PARTNER B9	Inform the driver Audio Communication	Switch module at the steering wheel																																								
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HF-DV6DTED-89 CV																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HF-DV6DTED-89 CV																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HE-DV6DTED-89 CV																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HE-DV6DTED-89 CV																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	HDI_SID807_BR2 HDI_SID807_BR2 9HL																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 NFU																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 N6B																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 N6A																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 NFR																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HR HDI SID807																																							
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR SIEMENS SID803A																													V	V									
PARTNER B9	Engine Gearbox	Gearbox ECU	Auto gearbox AL4																																							
PARTNER B9	Engine Gearbox	Gearbox ECU	AM6 Euro5																																							
PARTNER B9	Engine Gearbox	Gearbox ECU	AT6 Euro5																																							
PARTNER B9	Engine Gearbox	Gearbox ECU	CFC300P																																							
PARTNER B9	Engine Gearbox	Gearbox ECU	BVA_AT8																																							
PARTNER B9	Vehicle protection Management of accesses	Engine relay unit																																								
PARTNER B9	Vehicle protection Management of accesses	Trailer relay unit																																								
PARTNER B9	Vehicle protection Management of accesses	Windscreen wiper																																								
PARTNER B9	Active and passive safety	ABS or ESP ECU	ESP 81																																							
PARTNER B9	Active and passive safety	ABS or ESP ECU	ESP MK 100															V	V	V																						
PARTNER B9	Active and passive safety	ABS or ESP ECU	90 ESP					V	V	V	V	V	V	V	V	V	V																									

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Or Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
PARTNER B9	Active and passive safety	Electric secondary brake																												V	V											
PARTNER B9	Active and passive safety	Airbag ECU																																								
BOXER	Engine(6th to 8th digit of VIN)	BMF PUMA	BMF HDI 4C																															V	V	V						
BOXER	Engine(6th to 8th digit of VIN)	EDC17CP52_UDS 3.0 HDI 180CV E5	EDC17CP52_UDS 3.0 HDI 180CV E5																															V			V	V	V	V	V
BOXER	Engine(6th to 8th digit of VIN)	SID208	SID208																															V				V			V
BOXER	ABSESP	ESP 90_F																																								
BOXER	ABSESP	ESP 81						V																																		
BOXER	ABSESP	ABS 81																																								
BOXER	Built-In system interface	Built-In system interface																																								
BOXER	Built-In system interface	Built-In system interface																																								
BOXER	LDWS	LDWS																																								
BIPPER	Engine(6th to 8th digit of VIN)	EDC16C34																																								
BIPPER	Engine(6th to 8th digit of VIN)	HDI_8DF3																																			V	V	V	V
BIPPER	Engine(6th to 8th digit of VIN)	BMF PUMA	BMF HDI 4C																															V	V	V						
BIPPER	Engine(6th to 8th digit of VIN)	EDC17CP52_UDS 3.0 HDI 180CV E5																																V			V	V	V	V	V
BIPPER	Engine(6th to 8th digit of VIN)	SID208																																V				V			V
BIPPER	ABSESP	ESP 90_F																																								
BIPPER	ABSESP	ESP 81						V																																		
BIPPER	ABSESP	ABS 81																																								
BIPPER	Built-In system interface	Built-In system interface																																								
BIPPER	Built-In system interface	Built-In system interface																																								
BIPPER	Built-In system interface	Built-In system interface																																								
BIPPER	Airbag	Airbag																																								
BIPPER	LDWS	LDWS																																								
BIPPER	Instrument	Instrument																																								
BIPPER	Parking control	Parking control																																								
EXPERT	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																								
EXPERT	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																																								
EXPERT	Engine(6th to 8th digit of VIN)	DCM3.5_BR2		V	V	V	V																																			
EXPERT	Engine(6th to 8th digit of VIN)	SID807																																								
EXPERT	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																																								
EXPERT	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																																								
EXPERT	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																																								
EXPERT	Engine(6th to 8th digit of VIN)	MED17_4_4																																								
EXPERT	Engine(6th to 8th digit of VIN)	9HX EDC16C3																																								
EXPERT	Engine(6th to 8th digit of VIN)	9HY EDC16C3																																								
EXPERT	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																																								
EXPERT	Engine(6th to 8th digit of VIN)	9HV EDC16C3																																								
EXPERT	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																																								
EXPERT	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																																								

Vehicle	System 1	System 2	System 3	Change of engine block with the flowmeter	Replacement of the ancillary drive belt	Replacement of the exhaust manifold	Replacement of the cylinder head	Longitudinal acceleration sensor calibration	Replacement of the brake pads	First activation of the electric parking brake	Replacement of the rear right motorised brake caliper	Replacement of the rear left motorised brake caliper	Replacement of the electric parking brake RIGHT-hand actuator	Replacement of the electric parking brake LEFT-hand actuator	Defragmenting of the ESP ecu memory	Reactivation of automatic application of the electric parking brake	Deactivation of the automatic application of the EPB function	Calibration of the gyrometer / accelerometer sensor	Replacement of the ESP ECU	Bleeding of the hydraulic block ESP MK100	Initialisation	VIN code (Vehicle Identification Number)	Customer configuration	Vehicle configuration	Configuration of the personalisation menu	Filling Of The Additive Reservoir	Top Up Diesel Additive Tank	Replacement of diesel additive tank and fuel tank	Steering wheel angle sensor calibration	Brake cable replacement	Electric parking brake replacement	Initialization of the additive level when filling or replacing the additive reservoir	Replacement Of The Diesel Additive Reservoir Or Pump/Pipes	Oil Parameter Reinitialisation	Air conditioning or cruise control replacement	High pressure pump or flow regulation valve learning	Forced regeneration of the particle emission filter	Replacement of the EGR valve	Rail pressure sensor replacement	Oxygen sensor replacement	Replacement of the flowmeter
EXPERT	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																																								
EXPERT	Gearbox ECU	AM6 Euro5 automatic gearbox																																								
EXPERT	Gearbox ECU	AT6 Euro5 automatic gearbox																																								
EXPERT	Gearbox ECU	CFC300P gearbox																																								
EXPERT	Gearbox ECU	AL4 automatic gearbox																																								
EXPERT	Gearbox ECU	BVA_AM6_AT6_UDS																																								
EXPERT	Multiplexed additive adding pump ECU	Multiplexed additive adding pump ECU																																								
EXPERT	ABS or ESP ECU	ESP 81																																								
EXPERT	ABS or ESP ECU	90 ESP						V	V	V	V	V	V	V	V	V	V																									
EXPERT	ABS or ESP ECU	ESP MK 100																V	V	V																						
EXPERT	Headlamp height adjuster directional headlamp	Headlamp height adjuster/ directional headlamp																																								
EXPERT	Built-In system interface	Built-In system interface																																								
EXPERT	Built-In system interface	Built-In system interface																																								
EXPERT	Power steering electric pump unit	GEP																																								
EXPERT	Power steering electric pump unit	DAE_BVH2																																								
EXPERT	Battery charge status unit	BECB_GEN2																																								
EXPERT	Electric secondary brake	FSE																												V	V											
EXPERT	Engine relay unit	BSM																																								
EXPERT	Trailer relay unit	BSR																																								
EXPERT	Airbag ECU	RBG_UDS																																								
EXPERT	Airbag ECU	RBG_UDS																																								
EXPERT	Airbag ECU	SAC_AUTOLIV																																								
EXPERT	Instrument panel	COMBINE																																								
EXPERT	Instrument panel	COMBINE																																								
EXPERT	Rain-sunlight sensor	Rain and brightness sensor																																								
EXPERT	Rain-sunlight sensor	CDPL_UDS_HELLA																			V																					
EXPERT	Switch module at the steering wheel	COM2008P																																								
EXPERT	Switch module at the steering wheel	HDC																																								
EXPERT	Bodywork conversion unit	BTC																																								
EXPERT	Parking aid	AAS																																								
EXPERT	Additional heating	CHAUFF_ADD																																								
EXPERT	Telematics unit	SMEG_PLUS																																								
EXPERT	Anti-theft alarm	ALARME																																								
EXPERT	Rear air conditioning table	TAB_CLIM_AR																																								
EXPERT	Rain and brightness sensor	PLUIE_LUMINOSITE																																								
EXPERT	Supply protection and management unit	BPGA2010																																								
EXPERT	Door control pad	PDPC_UDS																																								
EXPERT	Air conditioning	BCC																																								
EXPERT	Touch screen	Touch screen																																								
EXPERT	Seat belts not fastened LED unit	TNB_2010																																								

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
107	Engine ECU	Petrol engine	ME795																
107	Gearbox ECU	MMT																	
107	Airbag	Airbag																	
107	ABS or ESP	ABS or ESP																	
107	Coded anti-start	ADC																	
107	Power steering	DAE																	
206	Built-In system interface	Built-In system interface																	
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	7LZ MM5NP																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	HFX J34P																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D J34P																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFX BOSCH MP7.3																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFX MM1AP																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LP																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME7.4.4																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME7.4.4 FLEX FUEL																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW ME749																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW ME749 BIOFLEX																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4 FLEX FUEL																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4 FLEX FUEL																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU or N6A or N6B ME749 BIO FLEX																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU J35																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFK MM6LP																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP																
206	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM4.8P																
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HX/8HZ BOSCH EDC16C3 EURO3																
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4																
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4																
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2																
206	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3																
206	Engines automatic gearbox	Diesel fuel additive control unit																	
206	Engines automatic gearbox	AL4 automatic gearbox																	
206	Engines automatic gearbox	AL4 automatic gearbox																	
206	Alarm	Alarm																	
206	Driver informationCommunication	Display/Telematics (AMF)																	
206	Driver informationCommunication	Display/Telematics (RT3)																	
206	Driver informationCommunication	Radio																	
206	Driver informationCommunication	CD Player																	
206	Driver informationCommunication	Instrument panel																	
206	Driver informationCommunication	Switching module steering wheel																	
206	Driver informationCommunication	On-board navigation system																	
206	VisibilityLighting	Driving school																	
206	VisibilityLighting	Rain/sunlight sensor																	
206	Airbag	Airbag SAC Central																	
206	Control the openings	Electric retractable roof																	
206	Heatingventilation	A/C																	
206	Active safety	ABS TEVES MK20																	
206	Active safety	ABS MK70																	
206	Active safety	ESP MK60																	
206	Electric pump unit (power steering)	Power steering																	
207	Driving assistance Comfort	Parking aid																	
207	Driving assistance Comfort	Heating/ventilation																	
207	Driving assistance Comfort	Under inflation detection																	
207	Driving assistance Comfort	Power steering																	
207	Built-In system interface	Built-In system interface																	
207	Inform the driver Audio Communication	Multifunction display																	
207	Inform the driver Audio Communication	Radio																	
207	Inform the driver Audio Communication	CD player																	
207	Inform the driver Audio Communication	Instrument panel																	
207	Inform the driver Audio Communication	Switch module at the steering wheel																	
207	Inform the driver Audio Communication	Warning light showing seat belt not fastened																	
207	Inform the driver Audio Communication	Battery charge status unit																	
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6B BOSCH ME7.4.5																
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FX MED 17.4																
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FY MED 17.4																

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LPC																
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4																
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV17.4																
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FR MEV17.4																
207	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FR MED17.4																
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4																
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4																
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV BOSCH EDC16C3																
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3																
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HL HDI SID807																
207	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HR HDI SID807																
207	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox																
207	Engine Gearbox	Gearbox ECU	Controlled manual gearbox (BVMP_MA)																
207	Engine Gearbox	Gearbox ECU	CFC300P																
207	Vehicle protection Management of accesses	Folding roof																	
207	Active and passive safety	ABS or ESP ECU																	
207	Active and passive safety	Airbag ECU																	
207	Visibility Lighting Signalling	Rain/sunlight sensor																	
207	Visibility Lighting Signalling	Static AFS																	
207	Visibility Lighting Signalling	Switch module at the steering wheel																	
208	Driving assistance Comfort	Electric power steering																	
208	Built-In system interface	Built-In system interface																	
208	Inform the driver Audio Communication	Multiplexed control panel																	
208	Inform the driver Audio Communication	External CD player																	
208	Inform the driver Audio Communication	Air conditioning																	
208	Inform the driver Audio Communication	Instrument panel																	
208	Inform the driver Audio Communication	Switch module at the steering wheel																	
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HP DV6DTED 92 CV																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HP DV6DTED 92 CV																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME749_EC5																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																
208	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																
208	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																
208	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																
208	Engine Gearbox	Gearbox ECU	CFC300P gearbox																
208	Engine Gearbox	Gearbox ECU	BVA_AL4																
208	Active and passive safety	ABS or ESP ECU																	
208	Active and passive safety	Airbag ECU																	
301	Driving assistance Comfort	Power steering																	
301	Driving assistance Comfort	Parking aid																	
301	Built-In system interface	Built-In system interface																	
301	Inform the driver Audio Communication	Multifunction display																	
301	Inform the driver Audio Communication	Radio																	
301	Inform the driver Audio Communication	Instrument panel																	
301	Inform the driver Audio Communication	Switch module at the steering wheel																	
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																
301	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																
301	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																
301	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																
301	Engine Gearbox	Gearbox ECU	CFC300P gearbox																
301	Engine Gearbox	Gearbox ECU	BVA_AT8																
301	Vehicle protection Management of accesses	Driver's door module																	
301	Active and passive safety	ABS or ESP ECU																	
301	Active and passive safety	Airbag ECU																	
307	Built-in systems interface	Built-in systems interface																	
307	Alarm	Alarm																	

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
307	Driver informationCommunication	Multifunction display																	
307	Driver informationCommunication	Parking aid																	
307	Driver informationCommunication	Radio																	
307	Driver informationCommunication	CD Player																	
307	Driver informationCommunication	Instrument panel																	
307	Driver informationCommunication	Switch module at the steering wheel																	
307	VisibilityLighting	Driving school																	
307	VisibilityLighting	Rain/sunlight sensor																	
307	VisibilityLighting	Switch module at the steering wheel																	
307	Airbag	Airbag ECU																	
307	Roll-over ECU	Roll-over ECU																	
307	Control the openings	Driver's door module																	
307	Control the openings	Passenger's door module																	
307	Control the openings	Folding roof																	
307	Heating ventilation	Air conditioning ECU																	
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000																
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	K6D SAGEM S2000																
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM48P (Mechanical throttle housing)																
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM4MP2 (Motorised butterfly)																
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	KFU MM6LP																
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFK MM6LP																
307	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP																
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3																
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3 EURO4																
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHS BOSCH EDC15C2																
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHZ BOSCH EDC15C2																
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801																
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHL SIEMENS SID 803																
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID 803																
307	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	9HT BOSCH EDC16C3																

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
307	Engines automatic gearbox	Diesel fuel additive control unit																	
307	Engines automatic gearbox	AL4 gearbox																	
307	Engines automatic gearbox	AL4 gearbox																	
307	Active safety	ESP BOSCH 5.7																	
307	Active safety	ABS BOSCH 8																	
307	Active safety	ESP BOSCH 8																	
307	Active safety	ABS 81																	
307	Electric pump unit (power steering)	Power steering																	
308	Driving assistance Comfort	Heating/ventilation																	
308	Driving assistance Comfort	Power steering																	
308	Driving assistance Comfort	Parking aid																	
308	Built-In system interface	Built-In system interface																	
308	Inform the driver Audio Communication	Multifunction display																	
308	Inform the driver Audio Communication	Radio																	
308	Inform the driver Audio Communication	Instrument panel																	
308	Inform the driver Audio Communication	Warning light showing seat belt not fastened																	
308	Inform the driver Audio Communication	Switch module at the steering wheel																	
308	Inform the driver Audio Communication	Battery charge status unit																	
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4																
308	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4 EVO																
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX EDC16C3																
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY EDC16C3																
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3																
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3																
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4																
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4																
308	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4																
308	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																
308	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																
308	Engine Gearbox	Gearbox ECU	CFC300P gearbox																
308	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox																
308	Engine Gearbox	Multiplexed additive adding pump ECU																	
308	Vehicle protection Management of accesses	Driver's door module																	
308	Active and passive safety	ABS or ESP ECU																	
308	Active and passive safety	Airbag ECU																	
308	Visibility Lighting Signalling	Rain/sunlight sensor																	
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	8FS MEV 17.4																
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4 EVO																

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
308(T9)	Engine Gearbox	Petrol (6th to 8th digit of VIN)	MED17_4_4																
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	EDC17C10_BR2																
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	EDC17C10_BR2																
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	SID807																
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	DCM3.5_BR2																
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX EDC16C3																
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY EDC16C3																
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3																
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3																
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4																
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4																
308(T9)	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4																
308(T9)	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																
308(T9)	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																
308(T9)	Engine Gearbox	Gearbox ECU	CFC300P gearbox																
308(T9)	Engine Gearbox	Gearbox ECU	AL4 automatic gearbox																
308(T9)	Engine Gearbox	Gearbox ECU	BVA_AM6_AT6_UDS																
308(T9)	Engine Gearbox	Multiplexed additive adding pump ECU																	
308(T9)	Headlamp height adjuster directional headlamp	LADCT																	
308(T9)	Built-In system interface	Built-In system interface																	
308(T9)	Switch module at the steering wheel	COM2008P																	
308(T9)	ABS or ESP ECU	90 ESP																	
308(T9)	ABS or ESP ECU	ESP 81																	
308(T9)	ABS or ESP ECU	ESP MK 100																	
308(T9)	Airbag ECU	RBG_UDS																	
308(T9)	Engine relay unit	Engine relay unit																	
308(T9)	Supply protection and management unit	BPGA2010																	
308(T9)	Door control pad	PDPC_UDS																	
308(T9)	Electric power steering	DAE_BVH2																	
308(T9)	Telematics unit SMEG_PLUS	SMEG_PLUS																	
308(T9)	Air conditioning	BCC																	
308(T9)	Controls on the steering wheel	Controls on the steering wheel																	
308(T9)	Touch screen	Touch screen																	
308(T9)	Rain-sunlight sensor	CDPL_UDS_HELLA																	
308(T9)	Seat belts not fastened LED unit	TNB_2010																	
405	Engine(6th to 8th digit of VIN)	L6A SAGEM SL96																	
405	Engine(6th to 8th digit of VIN)	1600RD SL96																	
405	Engine(6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																	
405	Engine(6th to 8th digit of VIN)	N6B BOSCH ME7.4.4																	
405	Engine(6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																	

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
405	Engine(6th to 8th digit of VIN)	LFZ SAGEM S2000																	
405	Engine(6th to 8th digit of VIN)	LFZ SAGEM S2000																	
405	Engine(6th to 8th digit of VIN)	1600RD SAGEM S2000																	
405	Engine(6th to 8th digit of VIN)	1600RD SAGEM S2000																	
405	Engine(6th to 8th digit of VIN)	LFY BOSCH MP7.3																	
405	Engine(6th to 8th digit of VIN)	NFU J35																	
406	Built-in systems interface	Built-in systems interface																	
406	Alarm	Alarm																	
406	Driver informationCommunication	Multifunction display																	
406	Driver informationCommunication	Instrument panel																	
406	Driver informationCommunication	Radio																	
406	Driver informationCommunication	CD Player																	
406	Driver informationCommunication	On-board navigation system																	
406	VisibilityLighting	Rain/sunlight sensor																	
406	Airbag	Airbag ECU																	
406	Heating ventilation	Air conditioning ECU																	
406	Active safety	ABS BOSCH 5.3																	
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	3FZ MM4MP2																
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	6FZ SAGEM S2000																
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	6FZ SAGEM S2000																
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	R6F MM 4.8P																
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	RFN MM 4.8P																
406	Engines automatic gearbox	Petrol (6th to 8th digit of VIN)	XFX BOSCH ME 7.4.6																
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	4HX BOSCH EDC15C2																
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHS BOSCH EDC15C2																
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHZ BOSCH EDC15C2																
406	Engines automatic gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID 801																
406	Engines automatic gearbox	Diesel fuel additive control unit																	
406	Engines automatic gearbox	Automatic gearbox																	
406	Engines automatic gearbox	Automatic gearbox																	
407	Driving assistance Comfort	Parking aid																	
407	Driving assistance Comfort	Heating/ventilation																	
407	Driving assistance Comfort	Under inflation detection																	
407	Driving assistance Comfort	Power steering																	
407	Built-In system interface	Built-In system interface																	
407	Inform the driver Audio Communication	Multifunction display	TYPE 'C'(DOT MATRIX)																
407	Inform the driver Audio Communication	Multifunction display	TYPE 'C COLOUR'(DOT MATRIX)																
407	Inform the driver Audio Communication	Radio																	
407	Inform the driver Audio Communication	CD player																	

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
407	Inform the driver Audio Communication	Instrument panel																	
407	Inform the driver Audio Communication	Switch module at the steering wheel																	
407	Inform the driver Audio Communication	Telematics																	
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	XFV ME747																
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	3FZ MM6LP																
407	Engine Gearbox	Petrol (6th to 8th digit of VIN)	RFN MM6LP																
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HV EDC16C3																
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR DCM 3.4																
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL DCM 3.4																
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHF DCM 3.4																
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHL SIEMENS SID 803																
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHR SIEMENS SID 803																
407	Engine Gearbox	Diesel (6th to 8th digit of VIN)	UHZ SID 201																
407	Engine Gearbox	Diesel fuel additive control unit																	
407	Engine Gearbox	Gearbox ECU	AM6 automatic gearbox																
407	Engine Gearbox	Gearbox ECU	BVA_AL4_AT8																
407	Engine Gearbox	Gearbox ECU	BVA_AL4_AT8																
407	Vehicle protection Management of accesses	Driver's door module																	
407	Vehicle protection Management of accesses	Passenger's door module																	
407	Vehicle protection Management of accesses	Sun roof																	
407	Active and passive safety	ABS or ESP ECU																	
407	Active and passive safety	ABS or ESP ECU																	
407	Active and passive safety	Airbag ECU																	
407	Visibility Lighting Signalling	Control unit Windscreen wipers																	
407	Visibility Lighting Signalling	Rain/sunlight sensor																	
3008	Driving assistance Comfort	High Head Vision																	
3008	Driving assistance Comfort	Assistance in complying with the inter-vehicle time (ARTIV)																	
3008	Driving assistance Comfort	Air conditioning ECU																	
3008	Driving assistance Comfort	Parking aid																	
3008	Driving assistance Comfort	Electropump assembly																	
3008	Driving assistance Comfort	Under inflation detection																	
3008	Driving assistance Comfort	Electric parking brake																	
3008	Built-In system interface	Built-In system interface																	
3008	Inform the driver Audio Communication	Multifunction display (EMF)																	
3008	Inform the driver Audio Communication	Switch module at the steering wheel																	
3008	Inform the driver Audio Communication	Radio																	
3008	Inform the driver Audio Communication	Instrument panel																	
3008	Inform the driver Audio Communication	Control panel dot matrix display																	
3008	Inform the driver Audio Communication	Battery charge status unit																	
3008	Inform the driver Audio Communication	Not Fastened warning light (TNB)																	

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FW MEV 17.4																
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FS MEV 17.4																
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FX MED 17.4																
3008	Engine Gearbox	Petrol (6th to 8th digit of VIN)	5FV MED 17.4																
3008	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ EDC16C3																
3008	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HD HDI_SID807_BR2																
3008	Engine Gearbox	Gearbox ECU	CFC300P gearbox																
3008	Engine Gearbox	Gearbox ECU	AM6 Euro5 automatic gearbox																
3008	Engine Gearbox	Gearbox ECU	AT6 Euro5 automatic gearbox																
3008	Engine Gearbox	Multiplexed additive adding pump ECU																	
3008	Vehicle protection Management of accesses	Driver's door module																	
3008	Active and passive safety	ABS or ESP ECU																	
3008	Active and passive safety	Airbag ECU																	
3008	Visibility Lighting Signalling	Rain sensor																	
3008	Visibility Lighting Signalling	Windscreen wiper																	
5008	Driving assistance Comfort	Power steering																	
5008	Driving assistance Comfort	Parking aid																	
5008	Built-In system interface	Built-In system interface																	
5008	Inform the driver Audio Communication	Multifunction display																	
5008	Inform the driver Audio Communication	Radio																	
5008	Inform the driver Audio Communication	Instrument panel																	
5008	Inform the driver Audio Communication	Switch module at the steering wheel																	
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HR HDI SID807																
5008	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR SIEMENS SID803A																
5008	Engine Gearbox	Gearbox ECU	Auto gearbox AL4																
5008	Engine Gearbox	Gearbox ECU	AM6 Euro5																
5008	Engine Gearbox	Gearbox ECU	AT6 Euro5																
5008	Engine Gearbox	Gearbox ECU	CFC300P																
5008	Engine Gearbox	Gearbox ECU	BVA_AT8																
5008	Vehicle protection Management of accesses	Engine relay unit																	

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
5008	Vehicle protection Management of accesses	Trailer relay unit																	
5008	Vehicle protection Management of accesses	Windscreen wiper																	
5008	Active and passive safety	ABS or ESP ECU																	
5008	Active and passive safety	Electric secondary brake																	
5008	Active and passive safety	Airbag ECU																	
PARTNER	Driving assistance Comfort	Parking aid																	
PARTNER	Built-In system interface	Built-In system interface																	
PARTNER	Driver information Communication	Display / Telematics																	
PARTNER	Driver information Communication	Radio																	
PARTNER	Driver information Communication	CD Player																	
PARTNER	Driver information Communication	Instrument panel																	
PARTNER	Driver information Communication	Switching module below steering wheel (COM 2000)																	
PARTNER	Airbags	Airbags																	
PARTNER	VisibilityLighting	Switching module below steering wheel (COM 2000)																	
PARTNER	VisibilityLighting	Rain/sunlight sensor																	
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	HFX MM4.8P																
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW SAGEM S2000PM2																
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.4																
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.4																
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME7.4.5																
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6B BOSCH ME7.4.5																
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU BOSCH ME7.4.5																
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	NFU or N6A BOSCH ME749																
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	N6A BOSCH ME749 BIO FLEX																
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME749																
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW BOSCH ME749 BIO FLEX																
PARTNER	Engine Gearbox	Petrol (6th to 8th digit of VIN)	KFW J34P																
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY SIEMENS SID801																
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	WJY LUCAS DCN2																
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	8HZ BOSCH EDC16C3 EURO4																
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HY BOSCH EDC16C3																
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HX BOSCH EDC16C3																
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HW BOSCH EDC16C3																
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	9HZ BOSCH EDC16C3																
PARTNER	Engine Gearbox	Diesel (6th to 8th digit of VIN)	RHY BOSCH EDC15C2																
PARTNER	Active Safety	ESP BOSCH 5.7																	
PARTNER	Active Safety	ABS BOSCH 8																	
PARTNER	Active Safety	ESP BOSCH 8																	
PARTNER	Active Safety	ABS 8.1																	

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
PARTNER	Active Safety	ESP 8.1																	
PARTNER B9	Driving assistance Comfort	Power steering																	
PARTNER B9	Driving assistance Comfort	Parking aid																	
PARTNER B9	Built-In system interface	Built-In system interface																	
PARTNER B9	Inform the driver Audio Communication	Multifunction display																	
PARTNER B9	Inform the driver Audio Communication	Bodywork conversion unit																	
PARTNER B9	Inform the driver Audio Communication	Instrument panel																	
PARTNER B9	Inform the driver Audio Communication	Switch module at the steering wheel																	
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HF-DV6DTED-89 CV																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HF-DV6DTED-89 CV																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HE-DV6DTED-89 CV																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	EDC17C10_BR2 9HE-DV6DTED-89 CV																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	HDI_SID807_BR2 HDI_SID807_BR2 9HL																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 NFU																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 N6B																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 N6A																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	ME745 NFR																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	5FV MED17.4.2 EURO 5																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	V46_21																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HX EDC16C3																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HY EDC16C3																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HV EDC16C3																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	9HR HDI SID807																
PARTNER B9	Engine Gearbox	Engine(6th to 8th digit of VIN)	RHR SIEMENS SID803A																
PARTNER B9	Engine Gearbox	Gearbox ECU	Auto gearbox AL4																
PARTNER B9	Engine Gearbox	Gearbox ECU	AM6 Euro5																
PARTNER B9	Engine Gearbox	Gearbox ECU	AT6 Euro5																
PARTNER B9	Engine Gearbox	Gearbox ECU	CFC300P																
PARTNER B9	Engine Gearbox	Gearbox ECU	BVA_AT8																
PARTNER B9	Vehicle protection Management of accesses	Engine relay unit																	
PARTNER B9	Vehicle protection Management of accesses	Trailer relay unit																	
PARTNER B9	Vehicle protection Management of accesses	Windscreen wiper																	
PARTNER B9	Active and passive safety	ABS or ESP ECU	ESP 81																
PARTNER B9	Active and passive safety	ABS or ESP ECU	ESP MK 100																
PARTNER B9	Active and passive safety	ABS or ESP ECU	90 ESP																

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
PARTNER B9	Active and passive safety	Electric secondary brake																	
PARTNER B9	Active and passive safety	Airbag ECU																	
BOXER	Engine(6th to 8th digit of VIN)	BMF PUMA	BMF HDI 4C																
BOXER	Engine(6th to 8th digit of VIN)	EDC17CP52_UDS 3.0 HDI 180CV E5	EDC17CP52_UDS 3.0 HDI 180CV E5	V	V	V													
BOXER	Engine(6th to 8th digit of VIN)	SID208	SID208				V	V	V	V	V	V							
BOXER	ABSESP	ESP 90_F											V	V					
BOXER	ABSESP	ESP 81																	
BOXER	ABSESP	ABS 81																	
BOXER	Built-In system interface	Built-In system interface																	
BOXER	Built-In system interface	Built-In system interface																	
BOXER	LDWS	LDWS																	
BIPPER	Engine(6th to 8th digit of VIN)	EDC16C34													V	V			
BIPPER	Engine(6th to 8th digit of VIN)	HDI_8DF3						V									V	V	V
BIPPER	Engine(6th to 8th digit of VIN)	BMF PUMA	BMF HDI 4C																
BIPPER	Engine(6th to 8th digit of VIN)	EDC17CP52_UDS 3.0 HDI 180CV E5		V	V	V													
BIPPER	Engine(6th to 8th digit of VIN)	SID208					V	V	V	V	V	V							
BIPPER	ABSESP	ESP 90_F											V	V					
BIPPER	ABSESP	ESP 81																	
BIPPER	ABSESP	ABS 81																	
BIPPER	Built-In system interface	Built-In system interface																	
BIPPER	Built-In system interface	Built-In system interface																	
BIPPER	Built-In system interface	Built-In system interface																	
BIPPER	Airbag	Airbag																	
BIPPER	LDWS	LDWS																	
BIPPER	Instrument	Instrument																	
BIPPER	Parking control	Parking control																	
EXPERT	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																	
EXPERT	Engine(6th to 8th digit of VIN)	EDC17C10_BR2																	
EXPERT	Engine(6th to 8th digit of VIN)	DCM3.5_BR2																	
EXPERT	Engine(6th to 8th digit of VIN)	SID807																	
EXPERT	Engine(6th to 8th digit of VIN)	5FW MEV 17.4																	
EXPERT	Engine(6th to 8th digit of VIN)	8FS MEV 17.4																	
EXPERT	Engine(6th to 8th digit of VIN)	5FS MEV 17.4 EVO																	
EXPERT	Engine(6th to 8th digit of VIN)	MED17_4_4																	
EXPERT	Engine(6th to 8th digit of VIN)	9HX EDC16C3																	
EXPERT	Engine(6th to 8th digit of VIN)	9HY EDC16C3																	
EXPERT	Engine(6th to 8th digit of VIN)	9HZ EDC16C3																	
EXPERT	Engine(6th to 8th digit of VIN)	9HV EDC16C3																	
EXPERT	Engine(6th to 8th digit of VIN)	RHR DCM 3.4																	
EXPERT	Engine(6th to 8th digit of VIN)	RHL DCM 3.4																	

Vehicle	System 1	System 2	System 3	Replacement of the turbocharger position sensor	Replacement of the clutch proportional sensor	Speed limiter that can be set	Replacement Of The Differential Pressure Sensor	Replacement of the air mixer	Replacement of the turbocharger	Forced regeneration of the particle filter+ vehicle stationary	Forced regeneration of the particle filter+ vehicle moving	Overhaul	Calibration of the longitudinal and lateral acceleration sensor	Decalibration of the longitudinal and lateral acceleration sensor	Replacement of the exhaust gas recycling valve	Re-Initialisation of the configuration	Particle filter replacement	Replacement of the engine flywheel	Oil wear counter zero reset
EXPERT	Engine(6th to 8th digit of VIN)	RHF DCM 3.4																	
EXPERT	Gearbox ECU	AM6 Euro5 automatic gearbox																	
EXPERT	Gearbox ECU	AT6 Euro5 automatic gearbox																	
EXPERT	Gearbox ECU	CFC300P gearbox																	
EXPERT	Gearbox ECU	AL4 automatic gearbox																	
EXPERT	Gearbox ECU	BVA_AM6_AT6_UDS																	
EXPERT	Multiplexed additive adding pump ECU	Multiplexed additive adding pump ECU																	
EXPERT	ABS or ESP ECU	ESP 81																	
EXPERT	ABS or ESP ECU	90 ESP																	
EXPERT	ABS or ESP ECU	ESP MK 100																	
EXPERT	Headlamp height adjuster directional headlamp	Headlamp height adjuster/ directional headlamp																	
EXPERT	Built-In system interface	Built-In system interface																	
EXPERT	Built-In system interface	Built-In system interface																	
EXPERT	Power steering electric pump unit	GEP																	
EXPERT	Power steering electric pump unit	DAE_BVH2																	
EXPERT	Battery charge status unit	BECB_GEN2																	
EXPERT	Electric secondary brake	FSE																	
EXPERT	Engine relay unit	BSM																	
EXPERT	Trailer relay unit	BSR																	
EXPERT	Airbag ECU	RBG_UDS																	
EXPERT	Airbag ECU	RBG_UDS																	
EXPERT	Airbag ECU	SAC_AUTOLIV																	
EXPERT	Instrument panel	COMBINE																	
EXPERT	Instrument panel	COMBINE																	
EXPERT	Rain-sunlight sensor	Rain and brightness sensor																	
EXPERT	Rain-sunlight sensor	CDPL_UDS_HELLA																	
EXPERT	Switch module at the steering wheel	COM2008P																	
EXPERT	Switch module at the steering wheel	HDC																	
EXPERT	Bodywork conversion unit	BTC																	
EXPERT	Parking aid	AAS																	
EXPERT	Additional heating	CHAUFF_ADD																	
EXPERT	Telematics unit	SMEG_PLUS																	
EXPERT	Anti-theft alarm	ALARME																	
EXPERT	Rear air conditioning table	TAB_CLIM_AR																	
EXPERT	Rain and brightness sensor	PLUIE_LUMINOSITE																	
EXPERT	Supply protection and management unit	BPGA2010																	
EXPERT	Door control pad	PDPC_UDS																	
EXPERT	Air conditioning	BCC																	
EXPERT	Touch screen	Touch screen																	
EXPERT	Seat belts not fastened LED unit	TNB_2010																	

Vehicle	SYSTEM1	SYSTEM2	SYSTEM3	DTC Analysis	DTC Clear	Data Analysis	Actuator	ECU INFORMATIN	Engine Key Code Registration, VIN Writing	Engine Key Code Reg	Keyless ID Reg	Key Registration	CVT Oil Degradation level	Operating Time	Remote Keyless Entry Initialization	Clear Alarm Trigger History	Alarm System	ATWS LED	Self Test	Extra reminder Cancel	Extra reminder Setting	Integrated Value Adjustment	Next Schedule Reminder Cancel	Periodic Reminder Schedule Set	Reminder Reset(Indicator Off)	Otional INT Schedule Setting	Learned Value Reset	THROTTLE BODY LEARNING	VARIANT CODING	FIRST INITIALISATION	ADJUST IDLE SPEED MANUAL OR AUTOMATIC P/N	ADJUST IDLE SPEED AUTO D	SIEMENS IMMOBILIZER KEY CODING	SIEMENS IMMOBILIZER KEY CLEAR	MISFIRE TEST	ADJUSTIGNITION TIMING	FUNCTION CODING	ALTER IDLE SPEED	READ OIL COUNT	READ OIL CHANGE DATE	READ AFTER SALES DATE	ADD_1001700	WRITE OIL CHANGE DATE	REINIT OIL COUNTER	REINIT AUTO ADAPTIVE	NOTE OIL COUNT	REINIT CONVERTOR LOCKUP ADAPIVE	EBC430 REPAIR CYCLE	Repair Bleeding	LOCKING OF IGNITION	UNLOCKING OF IGNITION	READ DATE OF AFTER SALES
Perdana	ENGINE(ECU)	MMC	STEP1	V	V																																															
Perdana	ENGINE(ECU)	MMC	STEP2	V	V																																															
Perdana	ENGINE(ECU)	MMC	STEP3	V	V	V	V	V																																												
Perdana	ENGINE(ECU)	MMC	STEP4	V	V																																															
Perdana	ATM(TCU)	MMC		V	V	V	V	V																																												
Perdana	ABS	MMC		V	V	V	V	V																																												
Perdana	ABS	TEVES MK20		V	V	V	V	V																																									V			
JUARA	ENGINE(ECU)	MMC	STEP1	V	V																																														
JUARA	ENGINE(ECU)	MMC	STEP2	V	V																																														
JUARA	ENGINE(ECU)	MMC	STEP3	V	V	V	V	V																																											
JUARA	ATM(TCU)	MMC_ISO		V	V	V		V																																											
JUARA	EPS	MMC_EPS		V	V	V	V	V																																											
WIRA	ENGINE(ECU)	EMS400		V	V	V	V	V																				V	V	V	V	V																			
WIRA	ENGINE(ECU)	MMC	STEP1	V	V																																														
WIRA	ENGINE(ECU)	MMC	STEP2	V	V																																														
WIRA	ENGINE(ECU)	MMC	STEP3	V	V	V	V	V																																											
WIRA	ENGINE(ECU)	MMC	STEP4	V	V																																														
WIRA	ATM(TCU)	MMC_ISO		V	V	V		V																																											
WIRA	ATM(TCU)	MMC		V	V	V	V	V																																											
WIRA	ABS	MMC		V	V	V	V	V																																											
PUTRA	IMMOBILISER	MMC																		V	V	V	V	V	V	V	V																								
WIRA	IMMOBILISER	SIEMENS		V	V	V		V																									V	V																	
SATRIA	ENGINE(ECU)	EMS400		V	V	V	V	V																				V	V	V	V	V																			
SATRIA	ENGINE(ECU)	MMC	STEP1	V	V																																														
SATRIA	ENGINE(ECU)	MMC	STEP2	V	V																																														
SATRIA	ENGINE(ECU)	MMC	STEP3	V	V	V	V	V																																											
SATRIA	ENGINE(ECU)	MMC	STEP4	V	V																																														
SATRIA	ATM(TCU)	MMC_ISO		V	V	V		V																																											
SATRIA	ATM(TCU)	MMC		V	V	V	V	V																																											
SATRIA	ABS	TEVES MK20		V	V	V	V	V																																								V			
SATRIA	IMMOBILISER	MMC																		V	V	V	V	V	V	V	V																								
SATRIA	IMMOBILISER	SIEMENS		V	V	V		V																									V	V																	
PUTRA	ENGINE(ECU)	MMC	STEP1	V	V																																														
PUTRA	ENGINE(ECU)	MMC	STEP2	V	V																																														
PUTRA	ENGINE(ECU)	MMC	STEP3	V	V	V	V	V																																											
PUTRA	ENGINE(ECU)	MMC	STEP4	V	V																																														
PUTRA	ATM(TCU)	MMC		V	V	V	V	V																																											
PUTRA	ABS	TEVES MK20		V	V	V	V	V																																								V			
PUTRA	IMMOBILISER	MMC																		V	V	V	V	V	V	V	V																								

Vehicle	SYSTEM1	SYSTEM2	SYSTEM3	DTC Analysis	DTC Clear	Data Analysis	Actuator	ECU INFORMATIN	Engine Key Code Registration, VIN Writing	Engine Key Code Reg	Keyless ID Reg	Key Registration	CVT Oil Degradation level	Operating Time	Remote Keyless Entry Initialization	Clear Alarm Trigger History	Alarm System	ATWS LED	Self Test	Extra reminder Cancel	Extra reminder Setting	Integrated Value Adjustment	Next Schedule Reminder Cancel	Periodic Reminder Schedule Set	Reminder Reset(Indicator Off)	Otional INT Schedule Setting	Learned Value Reset	THROTTLE BODY LEARNING	VARIANT CODING	FIRST INITIALISATION	ADJUST IDLE SPEED MANUAL OR AUTOMATIC P/N	ADJUST IDLE SPEED AUTO D	SIEMENS IMMOBILIZER KEY CODING	SIEMENS IMMOBILIZER KEY CLEAR	MISFIRE TEST	ADJUSTIGNITION TIMING	FUNCTION CODING	ALTER IDLE SPEED	READ OIL COUNT	READ OIL CHANGE DATE	READ AFTER SALES DATE	ADD_1001700	WRITE OIL CHANGE DATE	REINIT OIL COUNTER	REINIT AUTO ADAPTIVE	NOTE OIL COUNT	REINIT CONVERTOR LOCKUP ADAPIVE	EBC430 REPAIR CYCLE	Repair Bleeding	LOCKING OF IGNITION	UNLOCKING OF IGNITION	READ DATE OF AFTER SALES
PUTRA	IMMOBILISER	SIEMENS		V	V	V		V																									V	V																		
ARENA	ENGINE(ECU)	EMS400		V	V	V	V	V																				V	V	V	V	V																				
ARENA	ATM(TCU)	MMC_ISO		V	V	V		V																																												
ARENA	ATM(TCU)	MMC		V	V	V	V	V																																												
ARENA	IMMOBILISER	SIEMENS		V	V	V		V																									V	V																		
WAJA	ENGINE(ECU)	EMS700		V	V	V	V	V																				V	V	V	V	V			V	V	V															
WAJA	ENGINE(ECU)	MMC	STEP3	V	V	V	V	V																																												
WAJA	ENGINE(ECU)	MMC	STEP4	V	V																																															
WAJA	ENGINE(ECU)	RENAULT18		V	V	V	V	V																														V														
WAJA	ATM(TCU)	RENAULT18		V	V	V	V	V																															V	V	V	V	V	V	V	V	V					
WAJA	ATM(TCU)	MMC_ISO		V	V	V		V																																												
WAJA	ATM(TCU)	MMC		V	V	V	V	V																																												
WAJA	ABS	TRW		V	V	V	V	V																																								V				
WAJA	SRS-AIRBAG	AC3		V	V	V		V																																									V	V	V
WAJA	SRS-AIRBAG	AC6		V	V			V																																												
WAJA	IMMOBILISER	MMC		V	V	V		V																																												
WAJA	IMMOBILISER	SIEMENS		V	V	V		V																									V	V																		
GEN2	ENGINE(ECU)	EMS700		V	V	V	V	V																				V	V	V	V	V			V	V	V															
GEN2	ATM(TCU)	MMC_ISO		V	V	V		V																																												
GEN2	ABS	BOSCH		V	V	V		V																																									V			
GEN2	ABS	TRW		V	V	V	V	V																																							V				
GEN2	SRS-AIRBAG	AC3		V	V	V		V																																									V	V	V
GEN2	IMMOBILISER	SIEMENS		V	V	V		V																									V	V																		
CHANCELLOR	ENGINE(ECU)	MMC	STEP1	V	V																																														
CHANCELLOR	ENGINE(ECU)	MMC	STEP2	V	V																																														
CHANCELLOR	ENGINE(ECU)	MMC	STEP3	V	V	V	V	V																																												
CHANCELLOR	ENGINE(ECU)	MMC	STEP4	V	V																																														
CHANCELLOR	ATM(TCU)	MMC		V	V	V	V	V																																												
CHANCELLOR	ABS	TRW		V	V	V	V	V																																							V				
SAVVY	ENGINE(ECU)	RENAULT12		V	V	V	V	V																					V																							
SAVVY	ATM(TCU)	RENAULT12		V	V	V	V	V																																												
SAVVY	ABS	TEVES MK60		V	V	V		V																																												
SAVVY	SRS-AIRBAG	AC3		V	V	V		V																																									V	V	V
SATRIA NEO	ENGINE(ECU)	EMS700		V	V	V	V	V																				V	V	V	V	V			V	V	V															
SATRIA NEO	ATM(TCU)	MMC_ISO		V	V	V		V																																												
SATRIA NEO	ABS	BOSCH		V	V	V		V																																								V				
SATRIA NEO	SRS-AIRBAG	AC3		V	V	V		V																																									V	V	V
SATRIA NEO	IMMOBILISER	SIEMENS		V	V	V		V																									V	V																		
Persona	ENGINE(ECU)	OLD EMS700(TEST VERSION)		V	V	V	V	V																				V	V	V	V	V			V	V	V															

Vehicle	SYSTEM1	SYSTEM2	SYSTEM3	DTC Analysis	DTC Clear	Data Analysis	Actuator	ECU INFORMATIN	Engine Key Code Registration, VIN Writing	Engine Key Code Reg	Keyless ID Reg	Key Registration	CVT Oil Degradation level	Operating Time	Remote Keyless Entry Initialization	Clear Alarm Trigger History	Alarm System	ATWS LED	Self Test	Extra reminder Cancel	Extra reminder Setting	Integrated Value Adjustment	Next Schedule Reminder Cancel	Periodic Reminder Schedule Set	Reminder Reset(Indicator Off)	Otional INT Schedule Setting	Learned Value Reset	THROTTLE BODY LEARNING	VARIANT CODING	FIRST INITIALISATION	ADJUST IDLE SPEED MANUAL OR AUTOMATIC P/N	ADJUST IDLE SPEED AUTO D	SIEMENS IMMOBILIZER KEY CODING	SIEMENS IMMOBILIZER KEY CLEAR	MISFIRE TEST	ADJUSTIGNITION TIMING	FUNCTION CODING	ALTER IDLE SPEED	READ OIL COUNT	READ OIL CHANGE DATE	READ AFTER SALES DATE	ADD_1001700	WRITE OIL CHANGE DATE	REINIT OIL COUNTER	REINIT AUTO ADAPTIVE	NOTE OIL COUNT	REINIT CONVERTOR LOCKUP ADAPIVE	EBC430 REPAIR CYCLE	Repair Bleeding	LOCKING OF IGNITION	UNLOCKING OF IGNITION	READ DATE OF AFTER SALES
Persona	ENGINE(ECU)	NEW EMS700(TEST VERSION)		V	V	V	V	V																				V	V	V	V	V			V	V	V															
Persona	ATM(TCU)	MMC_ISO		V	V	V		V																																													
Persona	ABS	BOSCH		V	V	V		V																																											V		
Persona	SRS-AIRBAG	AC3		V	V	V		V																																												V	V	V
Persona	IMMOBILISER	SIEMENS		V	V	V		V																									V	V																			
SAGA	ENGINE(ECU)	EMS700(TEST VERSION)		V	V	V	V	V																				V	V	V	V	V			V	V	V															
SAGA	ATM(TCU)	MMC_ISO		V	V	V		V																																													
SAGA	SRS-AIRBAG	AC3		V	V	V		V																																												V	V	V
SAGA	IMMOBILISER(2009~)	SIEMENS		V	V	V		V																									V	V																			
EXSORA	ENGINE(ECU)	EMS700		V	V	V	V	V																				V	V	V	V	V			V	V	V															
EXSORA	ATM(TCU)	MMC_ISO		V	V	V		V																																													
EXSORA	ABS	TRW EBC450		V	V	V	V	V																																													
EXSORA	BCM	BCF Continental		V	V	V	V	V							V	V	V	V	V																																		
EXSORA	SRS	SMART II AOTILIV		V	V			V						V																																							
EXSORA	IMMOBILISER	SIEMENS		V	V	V		V																									V	V																			
Inspira	Engine	1.8		V	V	V	V	V																			V																											
Inspira	Engine	2.0		V	V	V	V	V																			V																											
Inspira	ATM(TCU)	-		V	V	V		V					V																																								
Inspira	ABS	-		V	V	V	V	V																																													
Inspira	SRS	-		V	V	V	V	V																																													
Inspira	AC	-		V	V	V	V	V																																													
Inspira	ETACS	-		V	V	V	V	V																																													
Inspira	Meter	-		V	V	V	V	V												V	V	V	V	V	V	V																											
Inspira	Immo	-		V	V			V	V	V	V	V																																									

Vehicle	SYSTEM1	SYSTEM2	SYSTEM3	WRITE DATE OF AFTER SALES	REINITIALISE PROGRAMMING	INJ CONTROL LOCKED	CHANGE SETTING LAST SERVICE DATE	CHANGE SETTING LAST CLUTCH REPLACEMENT	CHANGE SETTING INITIALISATION CLUTCH CLOSED POSITION	ERASE MENU RESET CLUTCH KISS POINT	ERASE MENU PROGRAMMING RESET	ERASE MENU INITIALISATION CLUTCH CLOSED POSITION	GEAR SHIFTING GRID SELF TEST	HYDRAULIC PUMP DISABLE SELF TEST	HYDRAULIC PUMP ENABLE SELF TEST	BLEED CLUTCH PHASE 1 SELF TEST	BLEED CLUTCH PHASE 2 SELF TEST	BLEED HYDRAULIC UNIT SELF TEST	FORCE NEUTRAL SELF TEST	TEST ALL ACTUATORS SELF TEST	FORCE REVERSE SELF TEST	PURGE PRESSURE ACCUMULATION SELF TEST	TEVES MK60 ABS BLEED	MMC IMMOBILLIZER KEY ID REGISTER	MMC IMMOBILLIZER CHANGE PASSWORD	Head lamp Auto leveling Diag mode	Customization	Customization Reset	Theft alarm	Emission Gas Mode	Sensor Calibration
Perdana	ENGINE(ECU)	MMC	STEP1																												
Perdana	ENGINE(ECU)	MMC	STEP2																												
Perdana	ENGINE(ECU)	MMC	STEP3																												
Perdana	ENGINE(ECU)	MMC	STEP4																												
Perdana	ATM(TCU)	MMC																													
Perdana	ABS	MMC																													
Perdana	ABS	TEVES MK20																													
JUARA	ENGINE(ECU)	MMC	STEP1																												
JUARA	ENGINE(ECU)	MMC	STEP2																												
JUARA	ENGINE(ECU)	MMC	STEP3																												
JUARA	ATM(TCU)	MMC_ISO																													
JUARA	EPS	MMC_EPS																													
WIRA	ENGINE(ECU)	EMS400																													
WIRA	ENGINE(ECU)	MMC	STEP1																												
WIRA	ENGINE(ECU)	MMC	STEP2																												
WIRA	ENGINE(ECU)	MMC	STEP3																												
WIRA	ENGINE(ECU)	MMC	STEP4																												
WIRA	ATM(TCU)	MMC_ISO																													
WIRA	ATM(TCU)	MMC																													
WIRA	ABS	MMC																													
PUTRA	IMMOBILISER	MMC																						V	V	V	V	V	V	V	V
WIRA	IMMOBILISER	SIEMENS																													
SATRIA	ENGINE(ECU)	EMS400																													
SATRIA	ENGINE(ECU)	MMC	STEP1																												
SATRIA	ENGINE(ECU)	MMC	STEP2																												
SATRIA	ENGINE(ECU)	MMC	STEP3																												
SATRIA	ENGINE(ECU)	MMC	STEP4																												
SATRIA	ATM(TCU)	MMC_ISO																													
SATRIA	ATM(TCU)	MMC																													
SATRIA	ABS	TEVES MK20																													
SATRIA	IMMOBILISER	MMC																						V	V	V	V	V	V	V	V
SATRIA	IMMOBILISER	SIEMENS																													
PUTRA	ENGINE(ECU)	MMC	STEP1																												
PUTRA	ENGINE(ECU)	MMC	STEP2																												
PUTRA	ENGINE(ECU)	MMC	STEP3																												
PUTRA	ENGINE(ECU)	MMC	STEP4																												
PUTRA	ATM(TCU)	MMC																													
PUTRA	ABS	TEVES MK20																													
PUTRA	IMMOBILISER	MMC																						V	V	V	V	V	V	V	V

Vehicle	SYSTEM1	SYSTEM2	SYSTEM3	WRITE DATE OF AFTER SALES	REINITIALISE PROGRAMMING	INJ CONTROL LOCKED	CHANGE SETTING LAST SERVICE DATE	CHANGE SETTING LAST CLUTCH REPLACEMENT	CHANGE SETTING INITIALISATION CLUTCH CLOSED POSITION	ERASE MENU RESET CLUTCH KISS POINT	ERASE MENU PROGRAMMING RESET	ERASE MENU INITIALISATION CLUTCH CLOSED POSITION	GEAR SHIFTING GRID SELF TEST	HYDRAULIC PUMP DISABLE SELF TEST	HYDRAULIC PUMP ENABLE SELF TEST	BLEED CLUTCH PHASE 1 SELF TEST	BLEED CLUTCH PHASE 2 SELF TEST	BLEED HYDRAULIC UNIT SELF TEST	FORCE NEUTRAL SELF TEST	TEST ALL ACTUATORS SELF TEST	FORCE REVERSE SELF TEST	PURGE PRESSURE ACCUMULATION SELF TEST	TEVES MK60 ABS BLEED	MMC IMMOBILLIZER KEY ID REGISTER	MMC IMMOBILLIZER CHANGE PASSWORD	Head lamp Auto leveling Diag mode	Customization	Customization Reset	Theft alarm	Emission Gas Mode	Sensor Calibration
PUTRA	IMMOBILISER	SIEMENS																													
ARENA	ENGINE(ECU)	EMS400																													
ARENA	ATM(TCU)	MMC_ISO																													
ARENA	ATM(TCU)	MMC																													
ARENA	IMMOBILISER	SIEMENS																													
WAJA	ENGINE(ECU)	EMS700																													
WAJA	ENGINE(ECU)	MMC	STEP3																												
WAJA	ENGINE(ECU)	MMC	STEP4																												
WAJA	ENGINE(ECU)	RENAULT18																													
WAJA	ATM(TCU)	RENAULT18																													
WAJA	ATM(TCU)	MMC_ISO																													
WAJA	ATM(TCU)	MMC																													
WAJA	ABS	TRW																													
WAJA	SRS-AIRBAG	AC3		V																											
WAJA	SRS-AIRBAG	AC6																													
WAJA	IMMOBILISER	MMC																													
WAJA	IMMOBILISER	SIEMENS																													
GEN2	ENGINE(ECU)	EMS700																													
GEN2	ATM(TCU)	MMC_ISO																													
GEN2	ABS	BOSCH																													
GEN2	ABS	TRW																													
GEN2	SRS-AIRBAG	AC3		V																											
GEN2	IMMOBILISER	SIEMENS																													
CHANCELLOR	ENGINE(ECU)	MMC	STEP1																												
CHANCELLOR	ENGINE(ECU)	MMC	STEP2																												
CHANCELLOR	ENGINE(ECU)	MMC	STEP3																												
CHANCELLOR	ENGINE(ECU)	MMC	STEP4																												
CHANCELLOR	ATM(TCU)	MMC																													
CHANCELLOR	ABS	TRW																													
SAVVY	ENGINE(ECU)	RENAULT12			V	V																									
SAVVY	ATM(TCU)	RENAULT12					V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V									
SAVVY	ABS	TEVES MK60																					V								
SAVVY	SRS-AIRBAG	AC3		V																											
SATRIA NEO	ENGINE(ECU)	EMS700																													
SATRIA NEO	ATM(TCU)	MMC_ISO																													
SATRIA NEO	ABS	BOSCH																													
SATRIA NEO	SRS-AIRBAG	AC3		V																											
SATRIA NEO	IMMOBILISER	SIEMENS																													
Persona	ENGINE(ECU)	OLD EMS700(TEST VERSION)																													

Vehicle	SYSTEM1	SYSTEM2	SYSTEM3	WRITE DATE OF AFTER SALES	REINITIALISE PROGRAMMING	INJ CONTROL LOCKED	CHANGE SETTING LAST SERVICE DATE	CHANGE SETTING LAST CLUTCH REPLACEMENT	CHANGE SETTING INITIALISATION CLUTCH CLOSED POSITION	ERASE MENU RESET CLUTCH KISS POINT	ERASE MENU PROGRAMMING RESET	ERASE MENU INITIALISATION CLUTCH CLOSED POSITION	GEAR SHIFTING GRID SELF TEST	HYDRAULIC PUMP DISABLE SELF TEST	HYDRAULIC PUMP ENABLE SELF TEST	BLEED CLUTCH PHASE 1 SELF TEST	BLEED CLUTCH PHASE 2 SELF TEST	BLEED HYDRAULIC UNIT SELF TEST	FORCE NEUTRAL SELF TEST	TEST ALL ACTUATORS SELF TEST	FORCE REVERSE SELF TEST	PURGE PRESSURE ACCUMULATION SELF TEST	TEVES MK60 ABS BLEED	MMC IMMOBILLIZER KEY ID REGISTER	MMC IMMOBILLIZER CHANGE PASSWORD	Head lamp Auto leveling Diag mode	Customization	Customization Reset	Theft alarm	Emission Gas Mode	Sensor Calibration
Persona	ENGINE(ECU)	NEW EMS700(TEST VERSION)																													
Persona	ATM(TCU)	MMC_ISO																													
Persona	ABS	BOSCH																													
Persona	SRS-AIRBAG	AC3		V																											
Persona	IMMOBILISER	SIEMENS																													
SAGA	ENGINE(ECU)	EMS700(TEST VERSION)																													
SAGA	ATM(TCU)	MMC_ISO																													
SAGA	SRS-AIRBAG	AC3		V																											
SAGA	IMMOBILISER(2009~)	SIEMENS																													
EXSORA	ENGINE(ECU)	EMS700																													
EXSORA	ATM(TCU)	MMC_ISO																													
EXSORA	ABS	TRW EBC450																													
EXSORA	BCM	BCF Continental																													
EXSORA	SRS	SMART II AOTILIV																													
EXSORA	IMMOBILISER	SIEMENS																													
Inspira	Engine	1.8																													
Inspira	Engine	2.0																													
Inspira	ATM(TCU)	-																													
Inspira	ABS	-																												V	V
Inspira	SRS	-																													
Inspira	AC	-																													
Inspira	ETACS	-																									V	V	V		
Inspira	Meter	-																								V					
Inspira	Immo	-																													

Vehicle	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	[Erase]Air damper valve programming	[Erase]Average air temperature	[Erase]EGR valve programming	[Erase]Engine adaptives	[Erase]Exhaust injector circuit	[Erase]Flywheel target programming	[Erase]Fuel supply prevention	[Erase]Particle filter relative pressure sensor	[Erase]Preheater unit	[Erase]Proportional richness sensor programming	[Erase]Rail pressure sensor adaptives	ABS solenoid valve	Acceleration Sensor	Activation of Connectivity Services	Adaptive value-A/F ratio	Adaptive vaule tps	Adaptives after regeneration particle filter	Adaptives after replacing cabin filter	After Particle Filter Regeneration with the Diag Tool	After Replacement of the Particle Filter	After Replacing the Computer without having Saved Data	After replacment of the particle filter	Air bleeding	Air damper valve programming	Air flowmeter programming	Air path programming	Alcohol level prog.	Anti-Theft Alarm Trigger S/W	Auto-adaptives	Automatic Relocking	Bleed Hydraulic Unit and Braking Circuits	Bleeding	Brake Lining Friction Learning	Brake Pressure Offset Sensor	Cabin filter regeneration	Cabin Filter Regeneration (DPF regeneration)	Calculate battery wear counters	Camshaft sensor programming	Caravan towing distance	Catalytic converter test	Check target teeth	Computer Initialisation	Computer Reinitialisation	Computer Reset	Configuration	Cruise control/speed limiter programming	Decrement idle speed	Distance before next oil change	ECU Memory
CLIO	CLIO II	Injection	V	V	V	V																																													V				
CLIO	CLIO II	A.B.S.	V	V	V	V																																																	
CLIO	CLIO II	Variable P.A.S.	V	V	V	V																																																	
CLIO	CLIO II	Immobilizer	V	V	V	V																																																	
CLIO	CLIO II	Connection Unit	V	V	V	V																																																	
CLIO	CLIO II	Airbag / Pretensioners	V	V	V	V																																																	
CLIO	CLIO II	Air Conditioning	V	V	V	V																																																	
CLIO	CLIO II	Discharge Lamp	V	V	V	V																																																	
CLIO	CLIO III	Injection	V	V	V	V																																																	
CLIO	CLIO III	A.B.S.	V	V	V	V																																																	
CLIO	CLIO III	Variable P.A.S.	V	V	V	V																																																	
CLIO	CLIO III	UCH	V	V	V	V																																																	
CLIO	CLIO III	Airbag / Pretensioners	V	V	V	V																																																	
CLIO	CLIO III	Instrument Panel	V	V	V	V																																																	
CLIO	CLIO III	UPC	V	V	V	V																																																	
CLIO	CLIO IV	Injection	V	V	V	V	V		V	V		V	V			V	V							V							V										V			V		V						V			
CLIO	CLIO IV	A.B.S.	V	V	V	V													V																					V							V								
CLIO	CLIO IV	Instrument panel	V	V	V	V																																										V							
CLIO	CLIO IV	UCH	V	V	V	V																																																	
CLIO	CLIO IV	Airbag / Pretensioners	V	V	V	V																																																	
CLIO	CLIO IV	Air Conditioning	V	V	V	V																																											V						
CLIO	CLIO IV	Automatic Gearbox	V	V	V	V																																																	
CLIO	CLIO IV	Variable P.A.S.	V	V	V	V																																																	
CLIO	CLIO IV	UPC	V	V	V	V																																																	
CLIO	CLIO IV	Parking Prox Can(AAP)	V	V	V	V																																																	
CLIO	CLIO IV	Telematic CTRL unit (TCU)	V	V	V	V														V																														V				
CLIO	CLIO IV	Hands-free module (HFM)	V	V	V	V																																																	
MODUS	MODUS	Injection	V	V	V	V	V			V	V	V	V	V									V	V								V									V			V								V			
MODUS	MODUS	A.B.S.	V	V	V	V																														V										V								
MODUS	MODUS	Instrument Panel	V	V	V	V																																															V		
MODUS	MODUS	UCH	V	V	V	V																																																	
MODUS	MODUS	Airbag / Pretensioners	V	V	V	V																																																	
MODUS	MODUS	Variable P.A.S.	V	V	V	V																																																	
MODUS	MODUS	UPC	V	V	V	V																																																	
FLUENCE	FLUENCE	Injection	V	V	V	V																																						V											
FLUENCE	FLUENCE	Automatic Gearbox	V	V	V	V																												V																					
FLUENCE	FLUENCE	A.B.S.	V	V	V	V												V										V																			V							
FLUENCE	FLUENCE	Variable P.A.S.	V	V	V	V																																																	
FLUENCE	FLUENCE	UCH	V	V	V	V																																																	
FLUENCE	FLUENCE	Airbag / Pretensioners	V	V	V	V																																																	
FLUENCE	FLUENCE	Air Conditioning	V	V	V	V																																																	
FLUENCE	FLUENCE	Instrument Panel	V	V	V	V																																																V	

Vehicle	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	[Erase]Air damper valve programming	[Erase]Average air temperature	[Erase]EGR valve programming	[Erase]Engine adaptives	[Erase]Exhaust injector circuit	[Erase]Flywheel target programming	[Erase]Fuel supply prevention	[Erase]Particle filter relative pressure sensor	[Erase]Preheater unit	[Erase]Proportional richness sensor programming	[Erase]Rail pressure sensor adaptives	ABS solenoid valve	Acceleration Sensor	Activation of Connectivity Services	Adaptive value-A/F ratio	Adaptive vaule tps	Adaptives after regeneration particle filter	Adaptives after replacing cabin filter	After Particle Filter Regeneration with the Diag Tool	After Replacement of the Particle Filter	After Replacing the Computer without having Saved Data	After replacment of the particle filter	Air bleeding	Air damper valve programming	Air flowmeter programming	Air path programming	Alcohol level prog.	Anti-Theft Alarm Trigger S/W	Auto-adaptives	Automatic Relocking	Bleed Hydraulic Unit and Braking Circuits	Bleeding	Brake Lining Friction Learning	Brake Pressure Offset Sensor	Cabin filter regeneration	Cabin Filter Regeneration (DPF regeneration)	Calculate battery wear counters	Camshaft sensor programming	Caravan towing distance	Catalytic converter test	Check target teeth	Computer Initialisation	Computer Reinitialisation	Computer Reset	Configuration	Cruise control/speed limiter programming	Decrement idle speed	Distance before next oil change	ECU Memory
FLUENCE	FLUENCE	UPC	V	V	V	V																																																		
FLUENCE	FLUENCE	Sunroof	V	V	V	V																																																		
FLUENCE	FLUENCE	Parking aid	V	V	V	V																																																		
FLUENCE	FLUENCE	Driver's door	V	V	V	V																																											V							
KANGOO	KANGOO	Injection	V	V	V	V																																																		
KANGOO	KANGOO	A.B.S.	V	V	V	V																																																		
KANGOO	KANGOO	Immobilizer	V	V	V	V																																																		
KANGOO	KANGOO	Connection Unit	V	V	V	V																																																		
KANGOO	KANGOO	Airbag / Pretensioners	V	V	V	V																																																		
KANGOO	KANGOO MUX	Injection	V	V	V	V																																															V		
KANGOO	KANGOO MUX	Immobilizer	V	V	V	V																																																		
KANGOO	KANGOO MUX	Connection Unit	V	V	V	V																																																		
KANGOO	KANGOO MUX	Airbag / Pretensioners	V	V	V	V																																																		
KANGOO	KANGOO II	Injection	V	V	V	V	V		V	V	V	V	V	V			V						V	V								V									V			V								V			
KANGOO	KANGOO II	A.B.S.	V	V	V	V																														V																			
KANGOO	KANGOO II	Instrument Panel	V	V	V	V																																																		
KANGOO	KANGOO II	Immobilizer	V	V	V	V																																																		
KANGOO	KANGOO II	Airbag / Pretensioners	V	V	V	V																																																		
KANGOO	KANGOO II	Variable P.A.S.	V	V	V	V																																																		
KANGOO	KANGOO II	UPC	V	V	V	V																																																		
KANGOO	KANGOO PH2	Injection	V	V	V	V				V		V	V	V																														V												
KANGOO	KANGOO PH2	Instrument Panel	V	V	V	V																																																		
KANGOO	KANGOO PH2	UCH	V	V	V	V																																																		
KANGOO	KANGOO PH2	Airbag / Pretensioners	V	V	V	V																																																		
KANGOO	KANGOO PH2	Automatic Gearbox	V	V		V																																																		
KANGOO	KANGOO PH2	Variable P.A.S.	V	V		V																																																		
KOLEOS	KOLEOS	Injection	V	V	V	V																			V	V	V														V														V
KOLEOS	KOLEOS	Automatic Gearbox	V	V	V	V																																																		
KOLEOS	KOLEOS	A.B.S.	V	V	V	V																																																		
KOLEOS	KOLEOS	Variable P.A.S.	V	V	V	V																																																		
KOLEOS	KOLEOS	UCH	V	V	V	V																												V																						
KOLEOS	KOLEOS	Airbag / Pretensioners	V	V	V	V																																																		
KOLEOS	KOLEOS	Instrument Panel	V	V	V	V																																																	V	
KOLEOS	KOLEOS	UPC	V	V	V	V																																																		
KOLEOS	KOLEOS	Tyres	V	V	V	V																																																		
KOLEOS	KOLEOS	Parking Assistance	V	V	V	V																																																		
KOLEOS	KOLEOS	Parking Brake	V	V	V	V																																V																		
KOLEOS	KOLEOS	4 Wheel Drive	V	V	V	V																																																		
KOLEOS	KOLEOS	Radio	V	V	V	V																																																		
LAGUNA	LAGUNA II ph 2	Injection	V	V	V	V																																																		
LAGUNA	LAGUNA II ph 2	Automatic Gearbox	V	V	V	V																																																		
LAGUNA	LAGUNA II ph 2	A.B.S.	V	V	V	V																																																		

Vehicle	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	[Erase]Air damper valve programming	[Erase]Average air temperature	[Erase]EGR valve programming	[Erase]Engine adaptives	[Erase]Exhaust injector circuit	[Erase]Flywheel target programming	[Erase]Fuel supply prevention	[Erase]Particle filter relative pressure sensor	[Erase]Preheater unit	[Erase]Proportional richness sensor programming	[Erase]Rail pressure sensor adaptives	ABS solenoid valve	Acceleration Sensor	Activation of Connectivity Services	Adaptive value-A/F ratio	Adaptive vaule tps	Adaptives after regeneration particle filter	Adaptives after replacing cabin filter	After Particle Filter Regeneration with the Diag Tool	After Replacement of the Particle Filter	After Replacing the Computer without having Saved Data	After replacment of the particle filter	Air bleeding	Air damper valve programming	Air flowmeter programming	Air path programming	Alcohol level prog.	Anti-Theft Alarm Trigger S/W	Auto-adaptives	Automatic Relocking	Bleed Hydraulic Unit and Braking Circuits	Bleeding	Brake Lining Friction Learning	Brake Pressure Offset Sensor	Cabin filter regeneration	Cabin Filter Regeneration (DPF regeneration)	Calculate battery wear counters	Camshaft sensor programming	Caravan towing distance	Catalytic converter test	Check target teeth	Computer Initialisation	Computer Reinitialisation	Computer Reset	Configuration	Cruise control/speed limiter programming	Decrement idle speed	Distance before next oil change	ECU Memory
LAGUNA	LAGUNA II ph 2	UCH	V	V	V	V																																																		
LAGUNA	LAGUNA II ph 2	Airbag / Pretensioners	V	V	V	V																																																		
LAGUNA	LAGUNA II ph 2	Air Conditioning	V	V	V	V																																																		
LAGUNA	LAGUNA II ph 2	Instrument Panel	V	V	V	V																																																		
LAGUNA	LAGUNA II ph 2	Parking brake	V	V	V	V																																																		
LAGUNA	LAGUNA III	Injection	V	V	V	V																																														V			
LAGUNA	LAGUNA III	A.B.S.	V	V	V	V																																																		
LAGUNA	LAGUNA III	Instrument panel	V	V	V	V																																																		
LAGUNA	LAGUNA III	UCH	V	V	V	V																																																		
LAGUNA	LAGUNA III	Airbag / Pretensioners	V	V	V	V																																																		
LAGUNA	LAGUNA III	Air Conditioning	V	V	V	V																																																		
LAGUNA	LAGUNA III	Automatic Gearbox	V	V	V	V																																																		
LAGUNA	LAGUNA III	Parking brake	V	V	V	V																																																		
LAGUNA	LAGUNA III	UPC	V	V	V	V																																																		
LOGAN	LOGAN	Injection	V	V	V	V																	V	V						V											V															
LOGAN	LOGAN	GAS Injection	V	V	V	V																																																		
LOGAN	LOGAN	A.B.S.	V	V	V	V																															V											V								
LOGAN	LOGAN	Variable P.A.S.	V	V	V	V																																																		
LOGAN	LOGAN	UCH	V	V	V	V																														V																V				
LOGAN	LOGAN	Airbag / Pretensioners	V	V	V	V																																														V				
LOGAN	LOGAN II	Injection	V	V	V	V	V		V	V		V	V			V	V							V							V		V								V			V		V						V			
LOGAN	LOGAN II	A.B.S.	V	V	V	V													V																					V								V								
LOGAN	LOGAN II	Instrument Panel	V	V	V	V																																																		
LOGAN	LOGAN II	UCH	V	V	V	V																																																		
LOGAN	LOGAN II	Airbag / Pretensioners	V	V	V	V																																																		
LOGAN	LOGAN II	Air Conditioning	V	V	V	V																																												V						
LOGAN	LOGAN II	Variable P.A.S.	V	V	V	V																																																		
MEGANE	MEGANE	Injection	V	V	V	V																																														V			
MEGANE	MEGANE	A.B.S.	V	V	V	V																																																		
MEGANE	MEGANE	Immobilizer	V	V	V	V																																																		
MEGANE	MEGANE	Connection Unit	V	V	V	V																																																		
MEGANE	MEGANE	Airbag / Pretensioners	V	V	V	V																																																		
MEGANE	MEGANE II	Injection	V	V	V	V																																																		
MEGANE	MEGANE II	Automatic Gearbox	V	V	V	V																																																		
MEGANE	MEGANE II	A.B.S.	V	V	V	V																															V																			
MEGANE	MEGANE II	Variable P.A.S.	V	V	V	V																																																		
MEGANE	MEGANE II	UCH	V	V	V	V																																																		
MEGANE	MEGANE II	Airbag / Pretensioners	V	V	V	V																																																		
MEGANE	MEGANE II	Air Conditioning	V	V	V	V																																														V				
MEGANE	MEGANE II	Instrument Panel	V	V	V	V																																														V				
MEGANE	MEGANE II	UPC	V	V	V	V																																																		
MEGANE	MEGANE III	Injection	V	V	V	V																								V		V												V									V			

Vehicle	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	[Erase]Air damper valve programming	[Erase]Average air temperature	[Erase]EGR valve programming	[Erase]Engine adaptives	[Erase]Exhaust injector circuit	[Erase]Flywheel target programming	[Erase]Fuel supply prevention	[Erase]Particle filter relative pressure sensor	[Erase]Preheater unit	[Erase]Proportional richness sensor programming	[Erase]Rail pressure sensor adaptives	ABS solenoid valve	Acceleration Sensor	Activation of Connectivity Services	Adaptive value-A/F ratio	Adaptive vaule tps	Adaptives after regeneration particle filter	Adaptives after replacing cabin filter	After Particle Filter Regeneration with the Diag Tool	After Replacement of the Particle Filter	After Replacing the Computer without having Saved Data	After replacment of the particle filter	Air bleeding	Air damper valve programming	Air flowmeter programming	Air path programming	Alcohol level prog.	Anti-Theft Alarm Trigger S/W	Auto-adaptives	Automatic Relocking	Bleed Hydraulic Unit and Braking Circuits	Bleeding	Brake Lining Friction Learning	Brake Pressure Offset Sensor	Cabin filter regeneration	Cabin Filter Regeneration (DPF regeneration)	Calculate battery wear counters	Camshaft sensor programming	Caravan towing distance	Catalytic converter test	Check target teeth	Computer Initialisation	Computer Reinitialisation	Computer Reset	Configuration	Cruise control/speed limiter programming	Decrement idle speed	Distance before next oil change	ECU Memory
MEGANE	MEGANE III	Automatic Gearbox	V	V	V	V																																																		
MEGANE	MEGANE III	A.B.S.	V	V	V	V																																	V							V									
MEGANE	MEGANE III	Instrument Panel	V	V	V	V																																																	
MEGANE	MEGANE III	UCH	V	V	V	V																																																	
MEGANE	MEGANE III	Airbag / Pretensioners	V	V	V	V																																																	
MEGANE	MEGANE III	Air Conditioning	V	V	V	V																																																	
MEGANE	MEGANE III	Parking Brake	V	V	V	V																																																	
MEGANE	MEGANE III	UPC	V	V	V	V																																					V												
SANDERO	SANDERO	Injection	V	V	V	V																																																	
SANDERO	SANDERO	GAS Injection	V	V	V	V																																																	
SANDERO	SANDERO	A.B.S.	V	V	V	V																														V										V								
SANDERO	SANDERO	Variable P.A.S.	V	V	V	V																																																	
SANDERO	SANDERO	UCH	V	V	V	V																																													V				
SANDERO	SANDERO	Airbag / Pretensioners	V	V	V	V																																													V				
SCENIC II	SCENIC	Injection	V	V	V	V																																													V				
SCENIC II	SCENIC	A.B.S.	V	V	V	V																																																	
SCENIC II	SCENIC	Immobilizer	V	V	V	V																																																	
SCENIC II	SCENIC	Connection Unit	V	V	V	V																																																	
SCENIC II	SCENIC	Airbag / Pretensioners	V	V	V	V																																																	
SCENIC II	SCENIC II	Injection	V	V	V	V																																																	
SCENIC II	SCENIC II	A.B.S.	V	V	V	V																																																	
SCENIC II	SCENIC II	Variable P.A.S.	V	V	V	V																																																	
SCENIC II	SCENIC II	UCH	V	V	V	V																																																	
SCENIC II	SCENIC II	Airbag / Pretensioners	V	V	V	V																																																	
SCENIC II	SCENIC II	Air Conditioning	V	V	V	V																																																	
SCENIC II	SCENIC II	Instrument Panel	V	V	V	V																																																	
SCENIC II	SCENIC II	UPC	V	V	V	V																																																	
SCENIC II	SCENIC II	Parking Assistance	V	V	V	V																																																	
SCENIC II	SCENIC III	Injection	V	V	V	V																								V		V												V								V			
SCENIC II	SCENIC III	Automatic Gearbox	V	V	V	V																																																		
SCENIC II	SCENIC III	A.B.S.	V	V	V	V																																	V							V									
SCENIC II	SCENIC III	Instrument Panel	V	V	V	V																																																	
SCENIC II	SCENIC III	UCH	V	V	V	V																																																	
SCENIC II	SCENIC III	Airbag / Pretensioners	V	V	V	V																																																	
SCENIC II	SCENIC III	Air Conditioning	V	V	V	V																																																	
SCENIC II	SCENIC III	Parking Brake	V	V	V	V																																																	
SCENIC II	SCENIC III	UPC	V	V	V	V																																					V												
THALIA/SYMBOL	THALIA/SYMBOL	Injection	V	V	V	V																																													V				
THALIA/SYMBOL	THALIA/SYMBOL	A.B.S.	V	V	V	V																																																	
THALIA/SYMBOL	THALIA/SYMBOL	Immobilizer	V	V	V	V																																																	
THALIA/SYMBOL	THALIA/SYMBOL	Connection Unit	V	V	V	V																																													V				
THALIA/SYMBOL	THALIA/SYMBOL	Airbag / Pretensioners	V	V	V	V																																																	

Vehicle	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	[Erase]Air damper valve programming	[Erase]Average air temperature	[Erase]EGR valve programming	[Erase]Engine adaptives	[Erase]Exhaust injector circuit	[Erase]Flywheel target programming	[Erase]Fuel supply prevention	[Erase]Particle filter relative pressure sensor	[Erase]Preheater unit	[Erase]Proportional richness sensor programming	[Erase]Rail pressure sensor adaptives	ABS solenoid valve	Acceleration Sensor	Activation of Connectivity Services	Adaptive value-A/F ratio	Adaptive vaule tps	Adaptives after regeneration particle filter	Adaptives after replacing cabin filter	After Particle Filter Regeneration with the Diag. Tool	After Replacement of the Particle Filter	After Replacing the Computer without having Saved Data	After replacment of the particle filter	Air bleeding	Air damper valve programming	Air flowmeter programming	Air path programming	Alcohol level prog.	Anti-Theft Alarm Trigger S/W	Auto-adaptives	Automatic Relocking	Bleed Hydraulic Unit and Braking Circuits	Bleeding	Brake Lining Friction Learning	Brake Pressure Offset Sensor	Cabin filter regeneration	Cabin Filter Regeneration (DPF regeneration)	Calculate battery wear counters	Camshaft sensor programming	Caravan towing distance	Catalytic converter test	Check target teeth	Computer Initialisation	Computer Reinitialisation	Computer Reset	Configuration	Cruise control/speed limiter programming	Decrement idle speed	Distance before next oil change	ECU Memory
THALIA/SYMBOL	THALIA/SYMBOL2	Injection	V	V	V	V																																																	
THALIA/SYMBOL	THALIA/SYMBOL2	A.B.S.	V	V	V	V																														V									V								
THALIA/SYMBOL	THALIA/SYMBOL2	Variable P.A.S.	V	V	V	V																																																
THALIA/SYMBOL	THALIA/SYMBOL2	UCH	V	V	V	V																																																
THALIA/SYMBOL	THALIA/SYMBOL2	Airbag / Pretensioners	V	V	V	V																																																
TRAFIC II	TRAFIC II	Injection	V	V	V	V																																												V			
TRAFIC II	TRAFIC II	A.B.S.	V	V	V	V																															V																
TRAFIC II	TRAFIC II	Immobilizer	V	V	V	V																																															
TRAFIC II	TRAFIC II	Connection Unit	V	V	V	V																													V																		
TRAFIC II	TRAFIC II	Airbag / Pretensioners	V	V	V	V																																															
TWINGO	TWINGO	Injection	V	V	V	V																																												V			
TWINGO	TWINGO	A.B.S.	V	V	V	V																																															
TWINGO	TWINGO	Immobilizer	V	V	V	V																																															
TWINGO	TWINGO	Connection Unit	V	V	V	V																																												V			
TWINGO	TWINGO	Airbag / Pretensioners	V	V	V	V																																															
MASTER	MASTER II PH1	Injection	V	V	V	V																																														V		
MASTER	MASTER II PH2	Injection	V	V	V	V																																														V		
MASTER	MASTER II PH3	Injection	V	V	V	V																			V		V	V													V														V
MASTER	MASTER II PH3	Injection	V	V	V	V																			V		V	V													V														V
MASTER	MASTER II PH3	Automatic Gearbox	V	V	V	V																																															
MASTER	MASTER II PH3	A.B.S.	V	V	V	V																															V																
MASTER	MASTER II PH3	UCH	V	V	V	V																																															
MASTER	MASTER II PH3	Airbag / Pretensioners	V	V	V	V																																															
MASTER	MASTER II PH3	TRACKER	V	V	V	V																																															
MASTER	MASTER II PH3	Adaptation Unit	V	V	V	V																																															
MASTER	MASTER II PH3	Suspension	V	V	V	V																																															
MASTER	MASTER II PH3	Parking Assistance	V	V	V	V																																															
MASTER	MASTER III	Injection	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V						V	V																	V													
MASTER	MASTER III	A.B.S.	V	V	V	V																															V									V								
MASTER	MASTER III	Instrument Panel	V	V	V	V																																															
MASTER	MASTER III	UCH	V	V	V	V																																															
MASTER	MASTER III	Airbag / Pretensioners	V	V	V	V																																															
MASTER	MASTER III	Air Conditioning	V	V	V	V																																											V			
MASTER	MASTER III	UPC	V	V	V	V																																															
LATITUDE	LATITUDE	Injection	V	V	V	V															V	V									V		V										V		V					V			V
LATITUDE	LATITUDE	A.B.S.	V	V	V	V																																		V						V								
LATITUDE	LATITUDE	Instrument panel	V	V	V	V																																															
LATITUDE	LATITUDE	UCH	V	V	V	V																																															
LATITUDE	LATITUDE	Airbag / Pretensioners	V	V	V	V																																															
LATITUDE	LATITUDE	Air Conditioning	V	V	V	V																																											V			
LATITUDE	LATITUDE	Parking brake	V	V	V	V																																															
LATITUDE	LATITUDE	UPC	V	V	V	V																																										V						

Vehicle	System 1	System 2	DTC Analysis	Data Analysis	Actuation Test	Identification	[Erase]Air damper valve programming	[Erase]Average air temperature	[Erase]EGR valve programming	[Erase]Engine adaptives	[Erase]Exhaust injector circuit	[Erase]Flywheel target programming	[Erase]Fuel supply prevention	[Erase]Particle filter relative pressure sensor	[Erase]Preheater unit	[Erase]Proportional richness sensor programming	[Erase]Rail pressure sensor adaptives	ABS solenoid valve	Acceleration Sensor	Activation of Connectivity Services	Adaptive value-A/F ratio	Adaptive vaule tps	Adaptives after regeneration particle filter	Adaptives after replacing cabin filter	After Particle Filter Regeneration with the Diag. Tool	After Replacement of the Particle Filter	After Replacing the Computer without having Saved Data	After replacment of the particle filter	Air bleeding	Air damper valve programming	Air flowmeter programming	Air path programming	Alcohol level prog.	Anti-Theft Alarm Trigger S/W	Auto-adaptives	Automatic Relocking	Bleed Hydraulic Unit and Braking Circuits	Bleeding	Brake Lining Friction Learning	Brake Pressure Offset Sensor	Cabin filter regeneration	Cabin Filter Regeneration (DPF regeneration)	Calculate battery wear counters	Camshaft sensor programming	Caravan towing distance	Catalytic converter test	Check target teeth	Computer Initialisation	Computer Reinitialisation	Computer Reset	Configuration	Cruise control/speed limiter programming	Decrement idle speed	Distance before next oil change	ECU Memory
LATITUDE	LATITUDE	Parking Assistance	V	V	V	V																																							V										
LATITUDE	LATITUDE	Driver's door	V	V	V	V																																																	
LATITUDE	LATITUDE	Passenger's door	V	V	V	V																																																	
LATITUDE	LATITUDE	Seat memory	V	V	V	V																																																	
LATITUDE	LATITUDE	Variable P.A.S.	V	V	V	V																																																	
DUSTER	DUSTER	Injection	V	V	V	V																								V		V	V										V								V			
DUSTER	DUSTER	Automatic Gearbox	V	V	V	V																												V																					
DUSTER	DUSTER	4 Wheel Drive	V	V	V	V																																									V								
DUSTER	DUSTER	Radio	V	V	V	V																																																	
DUSTER	DUSTER	A.B.S.	V	V	V	V																														V									V									
DUSTER	DUSTER	UCH	V	V	V	V																																																	
DUSTER	DUSTER	Airbag / Pretensioners	V	V	V	V																																																	
DUSTER	DUSTER	Variable P.A.S.	V	V	V	V																																																	
DUSTER	DUSTER PH2	Injection	V	V	V	V	V		V	V		V	V	V		V	V							V							V		V								V			V		V						V			
DUSTER	DUSTER PH2	A.B.S.	V	V	V	V													V																					V							V									
DUSTER	DUSTER PH2	Instrument Panel	V	V	V	V																																																	
DUSTER	DUSTER PH2	UCH	V	V	V	V																																																	
DUSTER	DUSTER PH2	Airbag / Pretensioners	V	V	V	V																																																	
DUSTER	DUSTER PH2	Variable P.A.S.	V	V	V	V																																																	
DOKKER	DOKKER	Injection	V	V	V	V							V			V																	V											V								V			
DOKKER	DOKKER	A.B.S.	V	V	V	V																																		V							V									
DOKKER	DOKKER	Instrument Panel	V	V	V	V																																																	
DOKKER	DOKKER	UCH	V	V	V	V																																																	
DOKKER	DOKKER	Airbag / Pretensioners	V	V	V	V																																																	
DOKKER	DOKKER	Variable P.A.S.	V	V	V	V																																																	

Vehicle	System 1	System 2	EGR adaptives	EGR Programming	EGR valve	EGR Valve (reinitialisation)	EGR valve programming	Engine Adaptives	Engine parameter adaptives	Enter injector codes	Enter injector codes (4 line command 4cylinder)	Erase auto-adaptive values	Erase ECU memory	Erase EGR adaptives	Erase idle regulation adaptives	Erase Pressure regulation adaptives	Erase programmed values	Erasing	Exhaust injector circuit	Flywheel Target Programming	Fuel flow regulator	Fuel gauge calibration	Fuel Pump Programming	Fuel Supply Prevention	Hill Start	Ignition coil adaptive	Immobilizer	Increment of idle speed	Injection prohibition	Injection pump adatatives	Injector Adaptives	Injector adaptives No.1	Injector adaptives No.2	Injector adaptives No.3	Injector adaptives No.4	Injector Coding	Injector cylinder 1	Injector cylinder 2	Injector cylinder 3	Injector cylinder 4	Injectors (reinitialisation)	Inlet flap	Inlet Flap (reinitialisation)	Lock Computer	Lock injector control	Longitudinal acceleration sensor offset	Manifold pressure sensor programming	modification of parameters after initialisation	Number of starting cycles	Odometer in Km	Odometer in Miles	Oil change interval in KM	Oil change interval in Months	Oil change range : current value in KM	Oil change range : current value in Months
CLIO	CLIO II	Injection																V																																						
CLIO	CLIO II	A.B.S.																																																						
CLIO	CLIO II	Variable P.A.S.																																																						
CLIO	CLIO II	Immobilizer																																																						
CLIO	CLIO II	Connection Unit																																																						
CLIO	CLIO II	Airbag / Pretensioners																																									V													
CLIO	CLIO II	Air Conditioning																																																						
CLIO	CLIO II	Discharge Lamp																																																						
CLIO	CLIO III	Injection																																	V																						
CLIO	CLIO III	A.B.S.																																																						
CLIO	CLIO III	Variable P.A.S.																																																						
CLIO	CLIO III	UCH																																																						
CLIO	CLIO III	Airbag / Pretensioners																																																						
CLIO	CLIO III	Instrument Panel																																																						
CLIO	CLIO III	UPC																																																						
CLIO	CLIO IV	Injection		V				V		V							V			V			V	V						V																		V						
CLIO	CLIO IV	A.B.S.																							V																					V									
CLIO	CLIO IV	Instrument panel																																																V	V				
CLIO	CLIO IV	UCH																																																						
CLIO	CLIO IV	Airbag / Pretensioners																																									V													
CLIO	CLIO IV	Air Conditioning																																																						
CLIO	CLIO IV	Automatic Gearbox																																																						
CLIO	CLIO IV	Variable P.A.S.																																																						
CLIO	CLIO IV	UPC																																																						
CLIO	CLIO IV	Parking Prox Can(AAP)																																																						
CLIO	CLIO IV	Telematic CTRL unit (TCU)																																																						
CLIO	CLIO IV	Hands-free module (HFM)																																																						
MODUS	MODUS	Injection					V			V						V					V					V					V					V									V											
MODUS	MODUS	A.B.S.																																																						
MODUS	MODUS	Instrument Panel																																																			V	V	V	V
MODUS	MODUS	UCH																																																						
MODUS	MODUS	Airbag / Pretensioners																																									V													
MODUS	MODUS	Variable P.A.S.																																																						
MODUS	MODUS	UPC																																																						
FLUENCE	FLUENCE	Injection						V												V				V								V	V	V	V																					
FLUENCE	FLUENCE	Automatic Gearbox										V																																												
FLUENCE	FLUENCE	A.B.S.																																																						
FLUENCE	FLUENCE	Variable P.A.S.																																																						
FLUENCE	FLUENCE	UCH																																																						
FLUENCE	FLUENCE	Airbag / Pretensioners																																																						
FLUENCE	FLUENCE	Air Conditioning																																																						
FLUENCE	FLUENCE	Instrument Panel																																																						

Vehicle	System 1	System 2	EGR adaptives	EGR Programming	EGR valve	EGR Valve (reinitialisation)	EGR valve programming	Engine Adaptives	Engine parameter adaptives	Enter injector codes	Enter injector codes (4 line command 4cylinder)	Erase auto-adaptive values	Erase ECU memory	Erase EGR adaptives	Erase idle regulation adaptives	Erase Pressure regulation adaptives	Erase programmed values	Erasing	Exhaust injector circuit	Flywheel Target Programming	Fuel flow regulator	Fuel gauge calibration	Fuel Pump Programming	Fuel Supply Prevention	Hill Start	Ignition coil adaptive	Immobilizer	Increment of idle speed	Injection prohibition	Injection pump adatatives	Injector Adaptives	Injector adaptives No.1	Injector adaptives No.2	Injector adaptives No.3	Injector adaptives No.4	Injector Coding	Injector cylinder 1	Injector cylinder 2	Injector cylinder 3	Injector cylinder 4	Injectors (reinitialisation)	Inlet flap	Inlet Flap (reinitialisation)	Lock Computer	Lock injector control	Longitudinal acceleration sensor offset	Manifold pressure sensor programming	modification of parameters after initialisation	Number of starting cycles	Odometer in Km	Odometer in Miles	Oil change interval in KM	Oil change interval in Months	Oil change range : current value in KM	Oil change range : current value in Months
FLUENCE	FLUENCE	UPC																																																							
FLUENCE	FLUENCE	Sunroof																																																							
FLUENCE	FLUENCE	Parking aid																																																							
FLUENCE	FLUENCE	Driver's door																																																							
KANGOO	KANGOO	Injection																V																	V																					
KANGOO	KANGOO	A.B.S.																																																							
KANGOO	KANGOO	Immobilizer																																																							
KANGOO	KANGOO	Connection Unit																																																							
KANGOO	KANGOO	Airbag / Pretensioners																																																							
KANGOO	KANGOO MUX	Injection					V		V									V										V	V						V																						
KANGOO	KANGOO MUX	Immobilizer																																																							
KANGOO	KANGOO MUX	Connection Unit																																																							
KANGOO	KANGOO MUX	Airbag / Pretensioners																																																							
KANGOO	KANGOO II	Injection								V						V					V					V					V					V								V													
KANGOO	KANGOO II	A.B.S.																																																							
KANGOO	KANGOO II	Instrument Panel																																																				V	V	V	V
KANGOO	KANGOO II	Immobilizer																																																							
KANGOO	KANGOO II	Airbag / Pretensioners																																									V														
KANGOO	KANGOO II	Variable P.A.S.																																																							
KANGOO	KANGOO II	UPC																																																							
KANGOO	KANGOO PH2	Injection																		V										V	V																										
KANGOO	KANGOO PH2	Instrument Panel																																																				V	V	V	V
KANGOO	KANGOO PH2	UCH																																																							
KANGOO	KANGOO PH2	Airbag / Pretensioners																																									V														
KANGOO	KANGOO PH2	Automatic Gearbox																																																							
KANGOO	KANGOO PH2	Variable P.A.S.																																																							
KOLEOS	KOLEOS	Injection				V				V														V																	V		V														
KOLEOS	KOLEOS	Automatic Gearbox																																																							
KOLEOS	KOLEOS	A.B.S.																																																							
KOLEOS	KOLEOS	Variable P.A.S.																																																							
KOLEOS	KOLEOS	UCH																																																							
KOLEOS	KOLEOS	Airbag / Pretensioners																																																							
KOLEOS	KOLEOS	Instrument Panel																																																							
KOLEOS	KOLEOS	UPC																																																							
KOLEOS	KOLEOS	Tyres																																																							
KOLEOS	KOLEOS	Parking Assistance																																																							
KOLEOS	KOLEOS	Parking Brake																																																							
KOLEOS	KOLEOS	4 Wheel Drive																																																							
KOLEOS	KOLEOS	Radio																																																							
LAGUNA	LAGUNA II ph 2	Injection								V		V					V																																								
LAGUNA	LAGUNA II ph 2	Automatic Gearbox																																																							
LAGUNA	LAGUNA II ph 2	A.B.S.																																																							

Vehicle	System 1	System 2	EGR adaptives	EGR Programming	EGR valve	EGR Valve (reinitialisation)	EGR valve programming	Engine Adaptives	Engine parameter adaptives	Enter injector codes	Enter injector codes (4 line command 4cylinder)	Erase auto-adaptive values	Erase ECU memory	Erase EGR adaptives	Erase idle regulation adaptives	Erase Pressure regulation adaptives	Erase programmed values	Erasing	Exhaust injector circuit	Flywheel Target Programming	Fuel flow regulator	Fuel gauge calibration	Fuel Pump Programming	Fuel Supply Prevention	Hill Start	Ignition coil adaptive	Immobilizer	Increment of idle speed	Injection prohibition	Injection pump adatatives	Injector Adaptives	Injector adaptives No.1	Injector adaptives No.2	Injector adaptives No.3	Injector adaptives No.4	Injector Coding	Injector cylinder 1	Injector cylinder 2	Injector cylinder 3	Injector cylinder 4	Injectors (reinitialisation)	Inlet flap	Inlet Flap (reinitialisation)	Lock Computer	Lock injector control	Longitudinal acceleration sensor offset	Manifold pressure sensor programming	modification of parameters after initialisation	Number of starting cycles	Odometer in Km	Odometer in Miles	Oil change interval in KM	Oil change interval in Months	Oil change range : current value in KM	Oil change range : current value in Months
LAGUNA	LAGUNA II ph 2	UCH																																																						
LAGUNA	LAGUNA II ph 2	Airbag / Pretensioners																																																						
LAGUNA	LAGUNA II ph 2	Air Conditioning																																																						
LAGUNA	LAGUNA II ph 2	Instrument Panel																				V																														V	V	V	V
LAGUNA	LAGUNA II ph 2	Parking brake																																																						
LAGUNA	LAGUNA III	Injection						V			V									V										V																	V		V						
LAGUNA	LAGUNA III	A.B.S.																																																						
LAGUNA	LAGUNA III	Instrument panel																																																						
LAGUNA	LAGUNA III	UCH																																																						
LAGUNA	LAGUNA III	Airbag / Pretensioners																																									V													
LAGUNA	LAGUNA III	Air Conditioning																																																						
LAGUNA	LAGUNA III	Automatic Gearbox										V																																												
LAGUNA	LAGUNA III	Parking brake																																																						
LAGUNA	LAGUNA III	UPC																																																						
LOGAN	LOGAN	Injection					V	V		V			V		V			V						V																					V											
LOGAN	LOGAN	GAS Injection																																																						
LOGAN	LOGAN	A.B.S.																																																						
LOGAN	LOGAN	Variable P.A.S.																																																						
LOGAN	LOGAN	UCH																									V																													
LOGAN	LOGAN	Airbag / Pretensioners																																									V													
LOGAN	LOGAN II	Injection		V				V		V							V			V			V	V							V	V	V	V	V														V							
LOGAN	LOGAN II	A.B.S.																							V																					V										
LOGAN	LOGAN II	Instrument Panel																																																						
LOGAN	LOGAN II	UCH																																																						
LOGAN	LOGAN II	Airbag / Pretensioners																																									V													
LOGAN	LOGAN II	Air Conditioning																																																						
LOGAN	LOGAN II	Variable P.A.S.																																																						
MEGANE	MEGANE	Injection																V																																						
MEGANE	MEGANE	A.B.S.																																																						
MEGANE	MEGANE	Immobilizer																																																						
MEGANE	MEGANE	Connection Unit																																																						
MEGANE	MEGANE	Airbag / Pretensioners																																																						
MEGANE	MEGANE II	Injection																																	V									V											
MEGANE	MEGANE II	Automatic Gearbox																																																						
MEGANE	MEGANE II	A.B.S.																																																						
MEGANE	MEGANE II	Variable P.A.S.																																																						
MEGANE	MEGANE II	UCH																																																						
MEGANE	MEGANE II	Airbag / Pretensioners																																									V													
MEGANE	MEGANE II	Air Conditioning																																																						
MEGANE	MEGANE II	Instrument Panel																																																				V	V		V
MEGANE	MEGANE II	UPC																																																						
MEGANE	MEGANE III	Injection					V	V		V									V	V	V			V								V	V	V	V																						

Vehicle	System 1	System 2	EGR adaptives	EGR Programming	EGR valve	EGR Valve (reinitialisation)	EGR valve programming	Engine Adaptives	Engine parameter adaptives	Enter injector codes	Enter injector codes (4 line command 4cylinder)	Erase auto-adaptive values	Erase ECU memory	Erase EGR adaptives	Erase idle regulation adaptives	Erase Pressure regulation adaptives	Erase programmed values	Erasing	Exhaust injector circuit	Flywheel Target Programming	Fuel flow regulator	Fuel gauge calibration	Fuel Pump Programming	Fuel Supply Prevention	Hill Start	Ignition coil adaptive	Immobilizer	Increment of idle speed	Injection prohibition	Injection pump adatatives	Injector Adaptives	Injector adaptives No.1	Injector adaptives No.2	Injector adaptives No.3	Injector adaptives No.4	Injector Coding	Injector cylinder 1	Injector cylinder 2	Injector cylinder 3	Injector cylinder 4	Injectors (reinitialisation)	Inlet flap	Inlet Flap (reinitialisation)	Lock Computer	Lock injector control	Longitudinal acceleration sensor offset	Manifold pressure sensor programming	modification of parameters after initialisation	Number of starting cycles	Odometer in Km	Odometer in Miles	Oil change interval in KM	Oil change interval in Months	Oil change range : current value in KM	Oil change range : current value in Months
MEGANE	MEGANE III	Automatic Gearbox																																																						
MEGANE	MEGANE III	A.B.S.																																											V										
MEGANE	MEGANE III	Instrument Panel																																																					
MEGANE	MEGANE III	UCH																																									V												
MEGANE	MEGANE III	Airbag / Pretensioners																																																					
MEGANE	MEGANE III	Air Conditioning																																																					
MEGANE	MEGANE III	Parking Brake																																																					
MEGANE	MEGANE III	UPC																																																					
SANDERO	SANDERO	Injection								V			V		V																													V										
SANDERO	SANDERO	GAS Injection																																																					
SANDERO	SANDERO	A.B.S.																																																					
SANDERO	SANDERO	Variable P.A.S.																																																					
SANDERO	SANDERO	UCH																									V																												
SANDERO	SANDERO	Airbag / Pretensioners																																									V												
SCENIC II	SCENIC	Injection																V																																					
SCENIC II	SCENIC	A.B.S.																																																					
SCENIC II	SCENIC	Immobilizer																																																					
SCENIC II	SCENIC	Connection Unit																																																					
SCENIC II	SCENIC	Airbag / Pretensioners																																																					
SCENIC II	SCENIC II	Injection																																	V																						
SCENIC II	SCENIC II	A.B.S.																																																					
SCENIC II	SCENIC II	Variable P.A.S.																																																					
SCENIC II	SCENIC II	UCH																																																					
SCENIC II	SCENIC II	Airbag / Pretensioners																																																					
SCENIC II	SCENIC II	Air Conditioning																																																					
SCENIC II	SCENIC II	Instrument Panel																																																					
SCENIC II	SCENIC II	UPC																																																					
SCENIC II	SCENIC II	Parking Assistance																																																					
SCENIC II	SCENIC III	Injection					V	V		V									V	V	V			V							V	V	V	V																						
SCENIC II	SCENIC III	Automatic Gearbox																																																					
SCENIC II	SCENIC III	A.B.S.																																											V										
SCENIC II	SCENIC III	Instrument Panel																																																					
SCENIC II	SCENIC III	UCH																																																					
SCENIC II	SCENIC III	Airbag / Pretensioners																																									V												
SCENIC II	SCENIC III	Air Conditioning																																																					
SCENIC II	SCENIC III	Parking Brake																																																					
SCENIC II	SCENIC III	UPC																																																					
THALIA/SYMBOL	THALIA/SYMBOL	Injection																V																																					
THALIA/SYMBOL	THALIA/SYMBOL	A.B.S.																																																					
THALIA/SYMBOL	THALIA/SYMBOL	Immobilizer																																																					
THALIA/SYMBOL	THALIA/SYMBOL	Connection Unit																																																					
THALIA/SYMBOL	THALIA/SYMBOL	Airbag / Pretensioners																																									V												

Vehicle	System 1	System 2	EGR adaptives	EGR Programming	EGR valve	EGR Valve (reinitialisation)	EGR valve programming	Engine Adaptives	Engine parameter adaptives	Enter injector codes	Enter injector codes (4 line command 4cylinder)	Erase auto-adaptive values	Erase ECU memory	Erase EGR adaptives	Erase idle regulation adaptives	Erase Pressure regulation adaptives	Erase programmed values	Erasing	Exhaust injector circuit	Flywheel Target Programming	Fuel flow regulator	Fuel gauge calibration	Fuel Pump Programming	Fuel Supply Prevention	Hill Start	Ignition coil adaptive	Immobilizer	Increment of idle speed	Injection prohibition	Injection pump adatatives	Injector Adaptives	Injector adaptives No.1	Injector adaptives No.2	Injector adaptives No.3	Injector adaptives No.4	Injector Coding	Injector cylinder 1	Injector cylinder 2	Injector cylinder 3	Injector cylinder 4	Injectors (reinitialisation)	Inlet flap	Inlet Flap (reinitialisation)	Lock Computer	Lock injector control	Longitudinal acceleration sensor offset	Manifold pressure sensor programming	modification of parameters after initialisation	Number of starting cycles	Odometer in Km	Odometer in Miles	Oil change interval in KM	Oil change interval in Months	Oil change range : current value in KM	Oil change range : current value in Months
THALIA/SYMBOL	THALIA/SYMBOL2	Injection								V				V		V																													V											
THALIA/SYMBOL	THALIA/SYMBOL2	A.B.S.																																																						
THALIA/SYMBOL	THALIA/SYMBOL2	Variable P.A.S.																																																						
THALIA/SYMBOL	THALIA/SYMBOL2	UCH																																																						
THALIA/SYMBOL	THALIA/SYMBOL2	Airbag / Pretensioners																																																						
TRAFIC II	TRAFIC II	Injection																																																						
TRAFIC II	TRAFIC II	A.B.S.																																																						
TRAFIC II	TRAFIC II	Immobilizer																																																						
TRAFIC II	TRAFIC II	Connection Unit																																																						
TRAFIC II	TRAFIC II	Airbag / Pretensioners																																																						
TWINGO	TWINGO	Injection																V																																						
TWINGO	TWINGO	A.B.S.																																																						
TWINGO	TWINGO	Immobilizer																																																						
TWINGO	TWINGO	Connection Unit																																																						
TWINGO	TWINGO	Airbag / Pretensioners																																										V												
MASTER	MASTER II PH1	Injection					V		V																		V																													
MASTER	MASTER II PH2	Injection					V		V	V																	V																													
MASTER	MASTER II PH3	Injection		V	V			V		V																										V	V	V	V		V														
MASTER	MASTER II PH3	Injection			V					V																										V	V	V	V		V														
MASTER	MASTER II PH3	Automatic Gearbox																																																						
MASTER	MASTER II PH3	A.B.S.																																																						
MASTER	MASTER II PH3	UCH																																																						
MASTER	MASTER II PH3	Airbag / Pretensioners																																																						
MASTER	MASTER II PH3	TRACKER																																																						
MASTER	MASTER II PH3	Adaptation Unit																																																						
MASTER	MASTER II PH3	Suspension																																																						
MASTER	MASTER II PH3	Parking Assistance																																																						
MASTER	MASTER III	Injection								V																																															
MASTER	MASTER III	A.B.S.																																																						
MASTER	MASTER III	Instrument Panel																																																			V	V		
MASTER	MASTER III	UCH																																																						
MASTER	MASTER III	Airbag / Pretensioners																																																						
MASTER	MASTER III	Air Conditioning																																																						
MASTER	MASTER III	UPC																																																						
LATITUDE	LATITUDE	Injection	V					V		V					V					V				V		V				V																			V							
LATITUDE	LATITUDE	A.B.S.																																																						
LATITUDE	LATITUDE	Instrument panel																																																						
LATITUDE	LATITUDE	UCH																																																						
LATITUDE	LATITUDE	Airbag / Pretensioners																																										V												
LATITUDE	LATITUDE	Air Conditioning																																																						
LATITUDE	LATITUDE	Parking brake																																																						
LATITUDE	LATITUDE	UPC																																																						

Vehicle	System 1	System 2	EGR adaptives	EGR Programming	EGR valve	EGR Valve (reinitialisation)	EGR valve programming	Engine Adaptives	Engine parameter adaptives	Enter injector codes	Enter injector codes (4 line command 4cylinder)	Erase auto-adaptive values	Erase ECU memory	Erase EGR adaptives	Erase idle regulation adaptives	Erase Pressure regulation adaptives	Erase programmed values	Erasing	Exhaust injector circuit	Flywheel Target Programming	Fuel flow regulator	Fuel gauge calibration	Fuel Pump Programming	Fuel Supply Prevention	Hill Start	Ignition coil adaptive	Immobilizer	Increment of idle speed	Injection prohibition	Injection pump adatatives	Injector Adaptives	Injector adaptives No.1	Injector adaptives No.2	Injector adaptives No.3	Injector adaptives No.4	Injector Coding	Injector cylinder 1	Injector cylinder 2	Injector cylinder 3	Injector cylinder 4	Injectors (reinitialisation)	Inlet flap	Inlet Flap (reinitialisation)	Lock Computer	Lock injector control	Longitudinal acceleration sensor offset	Manifold pressure sensor programming	modification of parameters after initialisation	Number of starting cycles	Odometer in Km	Odometer in Miles	Oil change interval in KM	Oil change interval in Months	Oil change range : current value in KM	Oil change range : current value in Months
LATITUDE	LATITUDE	Parking Assistance																																																						
LATITUDE	LATITUDE	Driver's door																																																						
LATITUDE	LATITUDE	Passenger's door																																																						
LATITUDE	LATITUDE	Seat memory																																																						
LATITUDE	LATITUDE	Variable P.A.S.																																																						
DUSTER	DUSTER	Injection					V	V		V									V	V	V			V																																
DUSTER	DUSTER	Automatic Gearbox																																																						
DUSTER	DUSTER	4 Wheel Drive																																													V									
DUSTER	DUSTER	Radio																																																						
DUSTER	DUSTER	A.B.S.																																																						
DUSTER	DUSTER	UCH																									V																													
DUSTER	DUSTER	Airbag / Pretensioners																																									V													
DUSTER	DUSTER	Variable P.A.S.																																																						
DUSTER	DUSTER PH2	Injection		V				V		V							V			V			V	V						V	V	V	V	V	V														V						
DUSTER	DUSTER PH2	A.B.S.																																											V										
DUSTER	DUSTER PH2	Instrument Panel																																																						
DUSTER	DUSTER PH2	UCH																																																						
DUSTER	DUSTER PH2	Airbag / Pretensioners																																									V													
DUSTER	DUSTER PH2	Variable P.A.S.																																																						
DOKKER	DOKKER	Injection		V				V		V										V			V	V							V																		V							
DOKKER	DOKKER	A.B.S.																																																						
DOKKER	DOKKER	Instrument Panel																																																						
DOKKER	DOKKER	UCH																																																						
DOKKER	DOKKER	Airbag / Pretensioners																																									V													
DOKKER	DOKKER	Variable P.A.S.																																																						

Vehicle	System 1	System 2	Oil change range:current value in km	Oil change range:current value in MONTHS	Particle filter relative pressure sensor	Passenger air bag locking mode	Pinking sensor programming	Pressure regularion adaptives	Prevention of electrical consumers	Program clutch open position	Programmed Values	Programming of seat stops	Programming Reinitialisation	Programming selection/Engaging zones	Programming the Codes of the Four Valves	Programming Throttle Limits	Proportional Richness Sensor Programming	Rail pressure sensor adaptives	Read Configuration	Rear Brake Unit Initialisation	Rear Brake Unit Repositioning	Refilling new pump body	Reset	Reset Oil Change Counter	Resetting Internal Protection	Restart the computer	Richness Regulation Programming	Sensor Configuration	Sensor offsets	Shoe Lining Energy Counter	Slope Sensor Adjustment	Speed Index	Start OBD test:catalytic converter	Start OBD test:O2 sensors	Steering Angle Sensor Initialisation	Steering Wheel Angle Offset Sensor	Steering Wheel Angle Sensor	Stop & start function configuration	Stop Fuel Supply Prevention	Transverse Acceleration Offset Sensor	Turbocharging programming	Unlock Computer	Unlock Injector Control	Update odometer	Valve set selection	Van fast idle speed decrease	Van fast idle speed increase	Vehicle function programming	Vehicle parameters	With airconditioning	With boiler	With passenger compartment heating resistor	With power steering electric pump unit	With thermoplungers	Without airconditioning
CLIO	CLIO II	Injection											V						V																																					
CLIO	CLIO II	A.B.S.																																																						
CLIO	CLIO II	Variable P.A.S.																																																						
CLIO	CLIO II	Immobilizer																																																						
CLIO	CLIO II	Connection Unit																	V																																				
CLIO	CLIO II	Airbag / Pretensioners																	V																								V												
CLIO	CLIO II	Air Conditioning																																																						
CLIO	CLIO II	Discharge Lamp																																																						
CLIO	CLIO III	Injection																																																						
CLIO	CLIO III	A.B.S.																																																						
CLIO	CLIO III	Variable P.A.S.																																																						
CLIO	CLIO III	UCH																																																						
CLIO	CLIO III	Airbag / Pretensioners																																																						
CLIO	CLIO III	Instrument Panel																																																						
CLIO	CLIO III	UPC																																																						
CLIO	CLIO IV	Injection														V	V		V								V																													
CLIO	CLIO IV	A.B.S.																	V				V									V				V	V			V															
CLIO	CLIO IV	Instrument panel																	V																																					
CLIO	CLIO IV	UCH																	V																																					
CLIO	CLIO IV	Airbag / Pretensioners																	V									V															V													
CLIO	CLIO IV	Air Conditioning																																																						
CLIO	CLIO IV	Automatic Gearbox																																																						
CLIO	CLIO IV	Variable P.A.S.																																																						
CLIO	CLIO IV	UPC																	V						V																															
CLIO	CLIO IV	Parking Prox Can(AAP)																	V																																					
CLIO	CLIO IV	Telematic CTRL unit (TCU)																																																						
CLIO	CLIO IV	Hands-free module (HFM)																	V																																					
MODUS	MODUS	Injection					V			V					V		V	V								V												V				V													
MODUS	MODUS	A.B.S.																																																						
MODUS	MODUS	Instrument Panel																	V																									V												
MODUS	MODUS	UCH																																																						
MODUS	MODUS	Airbag / Pretensioners																																									V													
MODUS	MODUS	Variable P.A.S.																																																						
MODUS	MODUS	UPC																	V																																V					
FLUENCE	FLUENCE	Injection						V																																																
FLUENCE	FLUENCE	Automatic Gearbox																																																						
FLUENCE	FLUENCE	A.B.S.											V																			V																								
FLUENCE	FLUENCE	Variable P.A.S.																																																						
FLUENCE	FLUENCE	UCH																	V																																					
FLUENCE	FLUENCE	Airbag / Pretensioners																																																						
FLUENCE	FLUENCE	Air Conditioning																																																						
FLUENCE	FLUENCE	Instrument Panel																																																						

Vehicle	System 1	System 2	Oil change range:current value in km	Oil change range:current value in MONTHS	Particle filter relative pressure sensor	Passenger air bag locking mode	Pinking sensor programming	Pressure regularion adaptives	Prevention of electrical consumers	Program clutch open position	Programmed Values	Programming of seat stops	Programming Reinitialisation	Programming selection/Engaging zones	Programming the Codes of the Four Valves	Programming Throttle Limits	Proportional Richness Sensor Programming	Rail pressure sensor adaptives	Read Configuration	Rear Brake Unit Initialisation	Rear Brake Unit Repositioning	Refilling new pump body	Reset	Reset Oil Change Counter	Resetting Internal Protection	Restart the computer	Richness Regulation Programming	Sensor Configuration	Sensor offsets	Shoe Lining Energy Counter	Slope Sensor Adjustment	Speed Index	Start OBD test:catalytic converter	Start OBD test:O2 sensors	Steering Angle Sensor Initialisation	Steering Wheel Angle Offset Sensor	Steering Wheel Angle Sensor	Stop & start function configuration	Stop Fuel Supply Prevention	Transverse Acceleration Offset Sensor	Turbocharging programming	Unlock Computer	Unlock Injector Control	Update odometer	Valve set selection	Van fast idle speed decrease	Van fast idle speed increase	Vehicle function programming	Vehicle parameters	With airconditioning	With boiler	With passenger compartment heating resistor	With power steering electric pump unit	With thermoplungers	Without airconditioning
FLUENCE	FLUENCE	UPC																																																							
FLUENCE	FLUENCE	Sunroof																																																							
FLUENCE	FLUENCE	Parking aid																																																							
FLUENCE	FLUENCE	Driver's door																																																							
KANGOO	KANGOO	Injection											V						V																																					
KANGOO	KANGOO	A.B.S.																																																							
KANGOO	KANGOO	Immobilizer																																																							
KANGOO	KANGOO	Connection Unit																																																							
KANGOO	KANGOO	Airbag / Pretensioners																																																							
KANGOO	KANGOO MUX	Injection							V				V						V			V																											V		V	V		V	V	V
KANGOO	KANGOO MUX	Immobilizer																																																							
KANGOO	KANGOO MUX	Connection Unit																																																							
KANGOO	KANGOO MUX	Airbag / Pretensioners																																																							
KANGOO	KANGOO II	Injection					V				V					V			V								V												V				V													
KANGOO	KANGOO II	A.B.S.																																																							
KANGOO	KANGOO II	Instrument Panel																								V																		V													
KANGOO	KANGOO II	Immobilizer																	V																																						
KANGOO	KANGOO II	Airbag / Pretensioners																																								V																
KANGOO	KANGOO II	Variable P.A.S.																	V																																						
KANGOO	KANGOO II	UPC																																																							
KANGOO	KANGOO PH2	Injection																									V																														
KANGOO	KANGOO PH2	Instrument Panel																								V																		V													
KANGOO	KANGOO PH2	UCH																																																							
KANGOO	KANGOO PH2	Airbag / Pretensioners																																								V																
KANGOO	KANGOO PH2	Automatic Gearbox																																																							
KANGOO	KANGOO PH2	Variable P.A.S.																																		V																					
KOLEOS	KOLEOS	Injection									V								V																				V																		
KOLEOS	KOLEOS	Automatic Gearbox																						V																																	
KOLEOS	KOLEOS	A.B.S.																																	V																						
KOLEOS	KOLEOS	Variable P.A.S.																																																							
KOLEOS	KOLEOS	UCH																	V																																						
KOLEOS	KOLEOS	Airbag / Pretensioners																																																							
KOLEOS	KOLEOS	Instrument Panel																	V												V																										
KOLEOS	KOLEOS	UPC																																																							
KOLEOS	KOLEOS	Tyres													V																																										
KOLEOS	KOLEOS	Parking Assistance																	V																																						
KOLEOS	KOLEOS	Parking Brake																	V	V	V									V																											
KOLEOS	KOLEOS	4 Wheel Drive																																																							
KOLEOS	KOLEOS	Radio																																																							
LAGUNA	LAGUNA II ph 2	Injection																	V																																						
LAGUNA	LAGUNA II ph 2	Automatic Gearbox																																																							
LAGUNA	LAGUNA II ph 2	A.B.S.																																																							

Vehicle	System 1	System 2	Oil change range:current value in km	Oil change range:current value in MONTHS	Particle filter relative pressure sensor	Passenger air bag locking mode	Pinking sensor programming	Pressure regularion adaptives	Prevention of electrical consumers	Program clutch open position	Programmed Values	Programming of seat stops	Programming Reinitialisation	Programming selection/Engaging zones	Programming the Codes of the Four Valves	Programming Throttle Limits	Proportional Richness Sensor Programming	Rail pressure sensor adaptives	Read Configuration	Rear Brake Unit Initialisation	Rear Brake Unit Repositioning	Refilling new pump body	Reset	Reset Oil Change Counter	Resetting Internal Protection	Restart the computer	Richness Regulation Programming	Sensor Configuration	Sensor offsets	Shoe Lining Energy Counter	Slope Sensor Adjustment	Speed Index	Start OBD test:catalytic converter	Start OBD test:O2 sensors	Steering Angle Sensor Initialisation	Steering Wheel Angle Offset Sensor	Steering Wheel Angle Sensor	Stop & start function configuration	Stop Fuel Supply Prevention	Transverse Acceleration Offset Sensor	Turbocharging programming	Unlock Computer	Unlock Injector Control	Update odometer	Valve set selection	Van fast idle speed decrease	Van fast idle speed increase	Vehicle function programming	Vehicle parameters	With airconditioning	With boiler	With passenger compartment heating resistor	With power steering electric pump unit	With thermoplungers	Without airconditioning
LAGUNA	LAGUNA II ph 2	UCH																																																						
LAGUNA	LAGUNA II ph 2	Airbag / Pretensioners																																																						
LAGUNA	LAGUNA II ph 2	Air Conditioning																																																						
LAGUNA	LAGUNA II ph 2	Instrument Panel																	V																									V											
LAGUNA	LAGUNA II ph 2	Parking brake																																																						
LAGUNA	LAGUNA III	Injection															V		V																						V															
LAGUNA	LAGUNA III	A.B.S.																																																						
LAGUNA	LAGUNA III	Instrument panel																	V																																					
LAGUNA	LAGUNA III	UCH																	V																										V											
LAGUNA	LAGUNA III	Airbag / Pretensioners				V													V																								V													
LAGUNA	LAGUNA III	Air Conditioning																	V																																					
LAGUNA	LAGUNA III	Automatic Gearbox																	V																																					
LAGUNA	LAGUNA III	Parking brake																	V																																					
LAGUNA	LAGUNA III	UPC																	V						V													V																		
LOGAN	LOGAN	Injection			V			V											V								V												V																		
LOGAN	LOGAN	GAS Injection																	V																																					
LOGAN	LOGAN	A.B.S.																														V																		V						
LOGAN	LOGAN	Variable P.A.S.																																																						
LOGAN	LOGAN	UCH																																																						
LOGAN	LOGAN	Airbag / Pretensioners																																									V													
LOGAN	LOGAN II	Injection						V								V	V		V								V																														
LOGAN	LOGAN II	A.B.S.																	V				V									V				V	V			V																
LOGAN	LOGAN II	Instrument Panel																																											V											
LOGAN	LOGAN II	UCH																	V																																					
LOGAN	LOGAN II	Airbag / Pretensioners																	V									V															V													
LOGAN	LOGAN II	Air Conditioning																																																						
LOGAN	LOGAN II	Variable P.A.S.																																																						
MEGANE	MEGANE	Injection											V						V																																					
MEGANE	MEGANE	A.B.S.																																																						
MEGANE	MEGANE	Immobilizer																																																						
MEGANE	MEGANE	Connection Unit																																																						
MEGANE	MEGANE	Airbag / Pretensioners																																																						
MEGANE	MEGANE II	Injection									V								V																										V											
MEGANE	MEGANE II	Automatic Gearbox																																																						
MEGANE	MEGANE II	A.B.S.																																																						
MEGANE	MEGANE II	Variable P.A.S.																																																						
MEGANE	MEGANE II	UCH																	V																																					
MEGANE	MEGANE II	Airbag / Pretensioners																	V																								V													
MEGANE	MEGANE II	Air Conditioning																																																						
MEGANE	MEGANE II	Instrument Panel	V																																									V											
MEGANE	MEGANE II	UPC																																																						
MEGANE	MEGANE III	Injection			V			V										V	V																																					

Vehicle	System 1	System 2	Oil change range:current value in km	Oil change range:current value in MONTHS	Particle filter relative pressure sensor	Passenger air bag locking mode	Pinking sensor programming	Pressure regularion adaptives	Prevention of electrical consumers	Program clutch open position	Programmed Values	Programming of seat stops	Programming Reinitialisation	Programming selection/Engaging zones	Programming the Codes of the Four Valves	Programming Throttle Limits	Proportional Richness Sensor Programming	Rail pressure sensor adaptives	Read Configuration	Rear Brake Unit Initialisation	Rear Brake Unit Repositioning	Refilling new pump body	Reset	Reset Oil Change Counter	Resetting Internal Protection	Restart the computer	Richness Regulation Programming	Sensor Configuration	Sensor offsets	Shoe Lining Energy Counter	Slope Sensor Adjustment	Speed Index	Start OBD test:catalytic converter	Start OBD test:O2 sensors	Steering Angle Sensor Initialisation	Steering Wheel Angle Offset Sensor	Steering Wheel Angle Sensor	Stop & start function configuration	Stop Fuel Supply Prevention	Transverse Acceleration Offset Sensor	Turbocharging programming	Unlock Computer	Unlock Injector Control	Update odometer	Valve set selection	Van fast idle speed decrease	Van fast idle speed increase	Vehicle function programming	Vehicle parameters	With airconditioning	With boiler	With passenger compartment heating resistor	With power steering electric pump unit	With thermoplungers	Without airconditioning
MEGANE	MEGANE III	Automatic Gearbox																																																						
MEGANE	MEGANE III	A.B.S.																	V													V				V				V															
MEGANE	MEGANE III	Instrument Panel																	V																																					
MEGANE	MEGANE III	UCH																																								V														
MEGANE	MEGANE III	Airbag / Pretensioners																																																						
MEGANE	MEGANE III	Air Conditioning																	V																																					
MEGANE	MEGANE III	Parking Brake																																																						
MEGANE	MEGANE III	UPC																							V																															
SANDERO	SANDERO	Injection																	V																																					
SANDERO	SANDERO	GAS Injection																	V																																					
SANDERO	SANDERO	A.B.S.																														V				V														V						
SANDERO	SANDERO	Variable P.A.S.																																																						
SANDERO	SANDERO	UCH																																																						
SANDERO	SANDERO	Airbag / Pretensioners																																								V														
SCENIC II	SCENIC	Injection											V						V																																					
SCENIC II	SCENIC	A.B.S.																																		V																				
SCENIC II	SCENIC	Immobilizer																																																						
SCENIC II	SCENIC	Connection Unit																																																						
SCENIC II	SCENIC	Airbag / Pretensioners																																																						
SCENIC II	SCENIC II	Injection																																																						
SCENIC II	SCENIC II	A.B.S.																																		V																				
SCENIC II	SCENIC II	Variable P.A.S.																																																						
SCENIC II	SCENIC II	UCH																																																						
SCENIC II	SCENIC II	Airbag / Pretensioners																																																						
SCENIC II	SCENIC II	Air Conditioning																																																						
SCENIC II	SCENIC II	Instrument Panel																																																						
SCENIC II	SCENIC II	UPC																																																						
SCENIC II	SCENIC II	Parking Assistance																																																						
SCENIC II	SCENIC III	Injection			V			V										V	V																																					
SCENIC II	SCENIC III	Automatic Gearbox																																																						
SCENIC II	SCENIC III	A.B.S.																	V													V				V				V																
SCENIC II	SCENIC III	Instrument Panel																	V																																					
SCENIC II	SCENIC III	UCH																																																						
SCENIC II	SCENIC III	Airbag / Pretensioners																																								V														
SCENIC II	SCENIC III	Air Conditioning																	V																																					
SCENIC II	SCENIC III	Parking Brake																																																						
SCENIC II	SCENIC III	UPC																							V																															
THALIA/SYMBOL	THALIA/SYMBOL	Injection											V						V																																					
THALIA/SYMBOL	THALIA/SYMBOL	A.B.S.																																		V																				
THALIA/SYMBOL	THALIA/SYMBOL	Immobilizer																																																						
THALIA/SYMBOL	THALIA/SYMBOL	Connection Unit																	V																																					
THALIA/SYMBOL	THALIA/SYMBOL	Airbag / Pretensioners																	V																							V														

Vehicle	System 1	System 2	Oil change range:current value in km	Oil change range:current value in MONTHS	Particle filter relative pressure sensor	Passenger air bag locking mode	Pinking sensor programming	Pressure regularion adaptives	Prevention of electrical consumers	Program clutch open position	Programmed Values	Programming of seat stops	Programming Reinitialisation	Programming selection/Engaging zones	Programming the Codes of the Four Valves	Programming Throttle Limits	Proportional Richness Sensor Programming	Rail pressure sensor adaptives	Read Configuration	Rear Brake Unit Initialisation	Rear Brake Unit Repositioning	Refilling new pump body	Reset	Reset Oil Change Counter	Resetting Internal Protection	Restart the computer	Richness Regulation Programming	Sensor Configuration	Sensor offsets	Shoe Lining Energy Counter	Slope Sensor Adjustment	Speed Index	Start OBD test:catalytic converter	Start OBD test:O2 sensors	Steering Angle Sensor Initialisation	Steering Wheel Angle Offset Sensor	Steering Wheel Angle Sensor	Stop & start function configuration	Stop Fuel Supply Prevention	Transverse Acceleration Offset Sensor	Turbocharging programming	Unlock Computer	Unlock Injector Control	Update odometer	Valve set selection	Van fast idle speed decrease	Van fast idle speed increase	Vehicle function programming	Vehicle parameters	With airconditioning	With boiler	With passenger compartment heating resistor	With power steering electric pump unit	With thermoplungers	Without airconditioning
THALIA/SYMBOL	THALIA/SYMBOL2	Injection																																																						
THALIA/SYMBOL	THALIA/SYMBOL2	A.B.S.																													V				V													V						
THALIA/SYMBOL	THALIA/SYMBOL2	Variable P.A.S.																	V																																				
THALIA/SYMBOL	THALIA/SYMBOL2	UCH																																																					
THALIA/SYMBOL	THALIA/SYMBOL2	Airbag / Pretensioners																	V																																				
TRAFIC II	TRAFIC II	Injection																	V																											V	V							
TRAFIC II	TRAFIC II	A.B.S.																													V																							
TRAFIC II	TRAFIC II	Immobilizer																																																					
TRAFIC II	TRAFIC II	Connection Unit																	V																																				
TRAFIC II	TRAFIC II	Airbag / Pretensioners																																																					
TWINGO	TWINGO	Injection											V						V																																				
TWINGO	TWINGO	A.B.S.																																	V																				
TWINGO	TWINGO	Immobilizer																																																					
TWINGO	TWINGO	Connection Unit																	V																																				
TWINGO	TWINGO	Airbag / Pretensioners																	V																								V												
MASTER	MASTER II PH1	Injection																	V																											V	V			V		V		V
MASTER	MASTER II PH2	Injection																	V																											V	V			V		V		V
MASTER	MASTER II PH3	Injection									V		V						V																											V	V							
MASTER	MASTER II PH3	Injection									V		V																																									
MASTER	MASTER II PH3	Automatic Gearbox								V				V																																								
MASTER	MASTER II PH3	A.B.S.																													V				V	V																	
MASTER	MASTER II PH3	UCH																	V																																				
MASTER	MASTER II PH3	Airbag / Pretensioners																	V																																				
MASTER	MASTER II PH3	TRACKER																	V																																				
MASTER	MASTER II PH3	Adaptation Unit																																																					
MASTER	MASTER II PH3	Suspension																																																					
MASTER	MASTER II PH3	Parking Assistance																	V																																				
MASTER	MASTER III	Injection																																																					
MASTER	MASTER III	A.B.S.																													V				V																			
MASTER	MASTER III	Instrument Panel	V	V																						V																		V										
MASTER	MASTER III	UCH																	V																																				
MASTER	MASTER III	Airbag / Pretensioners																																																					
MASTER	MASTER III	Air Conditioning																	V																																				
MASTER	MASTER III	UPC																	V																																				
LATITUDE	LATITUDE	Injection					V	V			V		V			V	V		V								V												V		V						V						
LATITUDE	LATITUDE	A.B.S.																	V													V			V	V			V															
LATITUDE	LATITUDE	Instrument panel																	V																																				
LATITUDE	LATITUDE	UCH																	V																																				
LATITUDE	LATITUDE	Airbag / Pretensioners																																									V												
LATITUDE	LATITUDE	Air Conditioning																	V																																				
LATITUDE	LATITUDE	Parking brake																	V																																				
LATITUDE	LATITUDE	UPC																	V						V																														

Vehicle	System 1	System 2	Oil change range:current value in km	Oil change range:current value in MONTHS	Particle filter relative pressure sensor	Passenger air bag locking mode	Pinking sensor programming	Pressure regularion adaptives	Prevention of electrical consumers	Program clutch open position	Programmed Values	Programming of seat stops	Programming Reinitialisation	Programming selection/Engaging zones	Programming the Codes of the Four Valves	Programming Throttle Limits	Proportional Richness Sensor Programming	Rail pressure sensor adaptives	Read Configuration	Rear Brake Unit Initialisation	Rear Brake Unit Repositioning	Refilling new pump body	Reset	Reset Oil Change Counter	Resetting Internal Protection	Restart the computer	Richness Regulation Programming	Sensor Configuration	Sensor offsets	Shoe Lining Energy Counter	Slope Sensor Adjustment	Speed Index	Start OBD test:catalytic converter	Start OBD test:O2 sensors	Steering Angle Sensor Initialisation	Steering Wheel Angle Offset Sensor	Steering Wheel Angle Sensor	Stop & start function configuration	Stop Fuel Supply Prevention	Transverse Acceleration Offset Sensor	Turbocharging programming	Unlock Computer	Unlock Injector Control	Update odometer	Valve set selection	Van fast idle speed decrease	Van fast idle speed increase	Vehicle function programming	Vehicle parameters	With airconditioning	With boiler	With passenger compartment heating resistor	With power steering electric pump unit	With thermoplungers	Without airconditioning
LATITUDE	LATITUDE	Parking Assistance																	V																																					
LATITUDE	LATITUDE	Driver's door																																																						
LATITUDE	LATITUDE	Passenger's door																																																						
LATITUDE	LATITUDE	Seat memory										V																																												
LATITUDE	LATITUDE	Variable P.A.S.																																																						
DUSTER	DUSTER	Injection			V			V					V			V		V	V								V						V	V					V																
DUSTER	DUSTER	Automatic Gearbox																																																						
DUSTER	DUSTER	4 Wheel Drive																														V																									
DUSTER	DUSTER	Radio																	V																																					
DUSTER	DUSTER	A.B.S.																											V			V																		V						
DUSTER	DUSTER	UCH																	V																																					
DUSTER	DUSTER	Airbag / Pretensioners																	V																								V													
DUSTER	DUSTER	Variable P.A.S.																	V																																					
DUSTER	DUSTER PH2	Injection						V								V	V		V								V																													
DUSTER	DUSTER PH2	A.B.S.																	V				V													V	V			V															
DUSTER	DUSTER PH2	Instrument Panel																																										V											
DUSTER	DUSTER PH2	UCH																	V																																					
DUSTER	DUSTER PH2	Airbag / Pretensioners																	V																								V													
DUSTER	DUSTER PH2	Variable P.A.S.																																																						
DOKKER	DOKKER	Injection														V	V		V								V																													
DOKKER	DOKKER	A.B.S.																	V																	V	V			V																
DOKKER	DOKKER	Instrument Panel																																										V											
DOKKER	DOKKER	UCH																	V																																					
DOKKER	DOKKER	Airbag / Pretensioners																	V									V															V													
DOKKER	DOKKER	Variable P.A.S.																																																						

Vehicle	System 1	System 2	Without boiler	Without passenger compartment heating resistor	Without power steering electric pump unit	Without thermoplungers	Write configuration	Write configuration [Flashing buzzer]	Write date new clutch fitted	Write Date of Last After Sales Operation	Write transmission oil change date	Write V.I.N	Originally fitted perimetric protection	De-ice function	Starter relay request	Illuminate hazard lamps upon impact	Raid function authorisation by diag	vehicle locked by autolock when driving	Timer courtesy light	Heated rear screen when driving	Airbag	Courtesy light timer	Key type	Second fitting alarm	Radio frequency function	Overspeed alarm for arabia	Engine type	Configuration privee 31	Interval variation with speed	Locking with key	Seat belt unfastened detection	Verrou logicel (software lock)	Central locking button type	Note Oil Wear Counter	With Swirl Flap	Oil Vapour Heater	Upstream Oxygen Sensor	Waste Gate Regulation	Stop And Start Function	Number Of Starting Cycles [RZ079]	Alternator Setpoint Voltage	Number Of Starting Cycles [VP343]	Configuration PRIVEE29	Air Flowmeter Programming	Adaptives On Air Intake Flap Fault	Particle Filter Pressure Diff. Sensor	Engine Adaptives [RZ002]	Engine Adaptives [RZ003]	Low Pressure EGR Valve Programming	Exhaust Flap Low Setting	High Pressure Pump Counter [RZ097]	Injection Pump Adaptatives [RZ077]	Injection Pump Adaptatives [RZ093]	Number Of Starting 1	Number Of Starting 2
CLIO	CLIO II	Injection																																																					
CLIO	CLIO II	A.B.S.								V																																												
CLIO	CLIO II	Variable P.A.S.																																																				
CLIO	CLIO II	Immobilizer																																																				
CLIO	CLIO II	Connection Unit																																																				
CLIO	CLIO II	Airbag / Pretensioners								V																																												
CLIO	CLIO II	Air Conditioning																																																				
CLIO	CLIO II	Discharge Lamp																																																				
CLIO	CLIO III	Injection																																																				
CLIO	CLIO III	A.B.S.																																																				
CLIO	CLIO III	Variable P.A.S.																																																				
CLIO	CLIO III	UCH																																																				
CLIO	CLIO III	Airbag / Pretensioners																																																				
CLIO	CLIO III	Instrument Panel																																																				
CLIO	CLIO III	UPC																																																				
CLIO	CLIO IV	Injection										V																							V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
CLIO	CLIO IV	A.B.S.								V		V																																											
CLIO	CLIO IV	Instrument panel					V					V																																											
CLIO	CLIO IV	UCH					V					V																																											
CLIO	CLIO IV	Airbag / Pretensioners																																																				
CLIO	CLIO IV	Air Conditioning										V																																										
CLIO	CLIO IV	Automatic Gearbox																																																				
CLIO	CLIO IV	Variable P.A.S.																																																				
CLIO	CLIO IV	UPC										V																																										
CLIO	CLIO IV	Parking Prox Can(AAP)					V					V																																											
CLIO	CLIO IV	Telematic CTRL unit (TCU)										V																																										
CLIO	CLIO IV	Hands-free module (HFM)																																																				
MODUS	MODUS	Injection																																																				
MODUS	MODUS	A.B.S.								V																																												
MODUS	MODUS	Instrument Panel																																																				
MODUS	MODUS	UCH																																																				
MODUS	MODUS	Airbag / Pretensioners								V																																												
MODUS	MODUS	Variable P.A.S.								V																																												
MODUS	MODUS	UPC																																																				
FLUENCE	FLUENCE	Injection																																																				
FLUENCE	FLUENCE	Automatic Gearbox								V																																												
FLUENCE	FLUENCE	A.B.S.								V																																												
FLUENCE	FLUENCE	Variable P.A.S.																																																				
FLUENCE	FLUENCE	UCH																																																				
FLUENCE	FLUENCE	Airbag / Pretensioners																																																				
FLUENCE	FLUENCE	Air Conditioning																																																				
FLUENCE	FLUENCE	Instrument Panel					V																																															

Vehicle	System 1	System 2	Without boiler	Without passenger compartment heating resistor	Without power steering electric pump unit	Without thermoplungers	Write configuration	Write configuration [Flashing buzzer]	Write date new clutch fitted	Write Date of Last After Sales Operation	Write transmission oil change date	Write V.I.N	Originally fitted perimetric protection	De-ice function	Starter relay request	Illuminate hazard lamps upon impact	Raid function authorisation by diag	vehicle locked by autolock when driving	Timer courtesy light	Heated rear screen when driving	Airbag	Courtesy light timer	Key type	Second fitting alarm	Radio frequency function	Overspeed alarm for arabia	Engine type	Configuration privee 31	Interval variation with speed	Locking with key	Seat belt unfastened detection	Verrou logicel (software lock)	Central locking button type	Note Oil Wear Counter	With Swirl Flap	Oil Vapour Heater	Upstream Oxygen Sensor	Waste Gate Regulation	Stop And Start Function	Number Of Starting Cycles [RZ079]	Alternator Setpoint Voltage	Number Of Starting Cycles [VP343]	Configuration PRIVEE29	Air Flowmeter Programming	Adaptives On Air Intake Flap Fault	Particle Filter Pressure Diff. Sensor	Engine Adaptives [RZ002]	Engine Adaptives [RZ003]	Low Pressure EGR Valve Programming	Exhaust Flap Low Setting	High Pressure Pump Counter [RZ097]	Injection Pump Adaptatives [RZ077]	Injection Pump Adaptatives [RZ093]	Number Of Starting 1	Number Of Starting 2
FLUENCE	FLUENCE	UPC																																																						
FLUENCE	FLUENCE	Sunroof																																																						
FLUENCE	FLUENCE	Parking aid																																																						
FLUENCE	FLUENCE	Driver's door																																																						
KANGOO	KANGOO	Injection																																																						
KANGOO	KANGOO	A.B.S.								V																																														
KANGOO	KANGOO	Immobilizer																																																						
KANGOO	KANGOO	Connection Unit																																																						
KANGOO	KANGOO	Airbag / Pretensioners																																																						
KANGOO	KANGOO MUX	Injection	V		V	V																																																		
KANGOO	KANGOO MUX	Immobilizer																																																						
KANGOO	KANGOO MUX	Connection Unit																																																						
KANGOO	KANGOO MUX	Airbag / Pretensioners																																																						
KANGOO	KANGOO II	Injection																																																						
KANGOO	KANGOO II	A.B.S.								V																																														
KANGOO	KANGOO II	Instrument Panel										V																																												
KANGOO	KANGOO II	Immobilizer																																																						
KANGOO	KANGOO II	Airbag / Pretensioners																																																						
KANGOO	KANGOO II	Variable P.A.S.								V		V																																												
KANGOO	KANGOO II	UPC								V																																														
KANGOO	KANGOO PH2	Injection										V																										V																		
KANGOO	KANGOO PH2	Instrument Panel										V																																												
KANGOO	KANGOO PH2	UCH																																																						
KANGOO	KANGOO PH2	Airbag / Pretensioners																																																						
KANGOO	KANGOO PH2	Automatic Gearbox																																																						
KANGOO	KANGOO PH2	Variable P.A.S.								V		V																																												
KOLEOS	KOLEOS	Injection																																																						
KOLEOS	KOLEOS	Automatic Gearbox																																																						
KOLEOS	KOLEOS	A.B.S.																																																						
KOLEOS	KOLEOS	Variable P.A.S.																																																						
KOLEOS	KOLEOS	UCH																																																						
KOLEOS	KOLEOS	Airbag / Pretensioners																																																						
KOLEOS	KOLEOS	Instrument Panel																																																						
KOLEOS	KOLEOS	UPC																																																						
KOLEOS	KOLEOS	Tyres																																																						
KOLEOS	KOLEOS	Parking Assistance								V																																														
KOLEOS	KOLEOS	Parking Brake																																																						
KOLEOS	KOLEOS	4 Wheel Drive																																																						
KOLEOS	KOLEOS	Radio																																																						
LAGUNA	LAGUNA II ph 2	Injection																																																						
LAGUNA	LAGUNA II ph 2	Automatic Gearbox																																																						
LAGUNA	LAGUNA II ph 2	A.B.S.																																																						

Vehicle	System 1	System 2	Without boiler	Without passenger compartment heating resistor	Without power steering electric pump unit	Without thermoplungers	Write configuration	Write configuration [Flashing buzzer]	Write date new clutch fitted	Write Date of Last After Sales Operation	Write transmission oil change date	Write V.I.N	Originally fitted perimetric protection	De-ice function	Starter relay request	Illuminate hazard lamps upon impact	Raid function authorisation by diag	vehicle locked by autolock when driving	Timer courtesy light	Heated rear screen when driving	Airbag	Courtesy light timer	Key type	Second fitting alarm	Radio frequency function	Overspeed alarm for arabia	Engine type	Configuration privee 31	Interval variation with speed	Locking with key	Seat belt unfastened detection	Verrou logicel (software lock)	Central locking button type	Note Oil Wear Counter	With Swirl Flap	Oil Vapour Heater	Upstream Oxygen Sensor	Waste Gate Regulation	Stop And Start Function	Number Of Starting Cycles [RZ079]	Alternator Setpoint Voltage	Number Of Starting Cycles [VP343]	Configuration PRIVEE29	Air Flowmeter Programming	Adaptives On Air Intake Flap Fault	Particle Filter Pressure Diff. Sensor	Engine Adaptives [RZ002]	Engine Adaptives [RZ003]	Low Pressure EGR Valve Programming	Exhaust Flap Low Setting	High Pressure Pump Counter [RZ097]	Injection Pump Adaptatives [RZ077]	Injection Pump Adaptatives [RZ093]	Number Of Starting 1	Number Of Starting 2
LAGUNA	LAGUNA II ph 2	UCH																																																				
LAGUNA	LAGUNA II ph 2	Airbag / Pretensioners																																																				
LAGUNA	LAGUNA II ph 2	Air Conditioning																																																				
LAGUNA	LAGUNA II ph 2	Instrument Panel																																																				
LAGUNA	LAGUNA II ph 2	Parking brake																																																				
LAGUNA	LAGUNA III	Injection																																																				
LAGUNA	LAGUNA III	A.B.S.																																																				
LAGUNA	LAGUNA III	Instrument panel																																																				
LAGUNA	LAGUNA III	UCH																																																				
LAGUNA	LAGUNA III	Airbag / Pretensioners																																																				
LAGUNA	LAGUNA III	Air Conditioning																																																				
LAGUNA	LAGUNA III	Automatic Gearbox																																																				
LAGUNA	LAGUNA III	Parking brake																																																				
LAGUNA	LAGUNA III	UPC																																																				
LOGAN	LOGAN	Injection																																																				
LOGAN	LOGAN	GAS Injection					V																																															
LOGAN	LOGAN	A.B.S.								V																																												
LOGAN	LOGAN	Variable P.A.S.								V																																												
LOGAN	LOGAN	UCH											V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																					
LOGAN	LOGAN	Airbag / Pretensioners																																																				
LOGAN	LOGAN II	Injection										V																							V	V	V	V	V	V	V	V			V	V		V	V	V	V	V	V	V	V
LOGAN	LOGAN II	A.B.S.								V		V																																											
LOGAN	LOGAN II	Instrument Panel																																																				
LOGAN	LOGAN II	UCH					V					V																																										
LOGAN	LOGAN II	Airbag / Pretensioners																																																				
LOGAN	LOGAN II	Air Conditioning										V																																										
LOGAN	LOGAN II	Variable P.A.S.								V		V																																										
MEGANE	MEGANE	Injection																																																				
MEGANE	MEGANE	A.B.S.																																																				
MEGANE	MEGANE	Immobilizer																																																				
MEGANE	MEGANE	Connection Unit																																																				
MEGANE	MEGANE	Airbag / Pretensioners																																																				
MEGANE	MEGANE II	Injection																																																				
MEGANE	MEGANE II	Automatic Gearbox								V	V	V																						V																					
MEGANE	MEGANE II	A.B.S.																																																				
MEGANE	MEGANE II	Variable P.A.S.																																																				
MEGANE	MEGANE II	UCH																																																				
MEGANE	MEGANE II	Airbag / Pretensioners																																																				
MEGANE	MEGANE II	Air Conditioning																																																				
MEGANE	MEGANE II	Instrument Panel																																																				
MEGANE	MEGANE II	UPC																																																				
MEGANE	MEGANE III	Injection																																																				

Vehicle	System 1	System 2	Without boiler	Without passenger compartment heating resistor	Without power steering electric pump unit	Without thermoplungers	Write configuration	Write configuration [Flashing buzzer]	Write date new clutch fitted	Write Date of Last After Sales Operation	Write transmission oil change date	Write V.I.N	Originally fitted perimetric protection	De-ice function	Starter relay request	Illuminate hazard lamps upon impact	Raid function authorisation by diag	vehicle locked by autolock when driving	Timer courtesy light	Heated rear screen when driving	Airbag	Courtesy light timer	Key type	Second fitting alarm	Radio frequency function	Overspeed alarm for arabia	Engine type	Configuration privee 31	Interval variation with speed	Locking with key	Seat belt unfastened detection	Verrou logicel (software lock)	Central locking button type	Note Oil Wear Counter	With Swirl Flap	Oil Vapour Heater	Upstream Oxygen Sensor	Waste Gate Regulation	Stop And Start Function	Number Of Starting Cycles [RZ079]	Alternator Setpoint Voltage	Number Of Starting Cycles [VP343]	Configuration PRIVEE29	Air Flowmeter Programming	Adaptives On Air Intake Flap Fault	Particle Filter Pressure Diff. Sensor	Engine Adaptives [RZ002]	Engine Adaptives [RZ003]	Low Pressure EGR Valve Programming	Exhaust Flap Low Setting	High Pressure Pump Counter [RZ097]	Injection Pump Adaptatives [RZ077]	Injection Pump Adaptatives [RZ093]	Number Of Starting 1	Number Of Starting 2
MEGANE	MEGANE III	Automatic Gearbox																																																						
MEGANE	MEGANE III	A.B.S.								V																																														
MEGANE	MEGANE III	Instrument Panel																																																						
MEGANE	MEGANE III	UCH																																																						
MEGANE	MEGANE III	Airbag / Pretensioners																																																						
MEGANE	MEGANE III	Air Conditioning																																																						
MEGANE	MEGANE III	Parking Brake																																																						
MEGANE	MEGANE III	UPC																																																						
SANDERO	SANDERO	Injection																																																						
SANDERO	SANDERO	GAS Injection																																																						
SANDERO	SANDERO	A.B.S.								V																																														
SANDERO	SANDERO	Variable P.A.S.								V																																														
SANDERO	SANDERO	UCH																																																						
SANDERO	SANDERO	Airbag / Pretensioners																																																						
SCENIC II	SCENIC	Injection																																																						
SCENIC II	SCENIC	A.B.S.																																																						
SCENIC II	SCENIC	Immobilizer																																																						
SCENIC II	SCENIC	Connection Unit																																																						
SCENIC II	SCENIC	Airbag / Pretensioners																																																						
SCENIC II	SCENIC II	Injection																																																						
SCENIC II	SCENIC II	A.B.S.																																																						
SCENIC II	SCENIC II	Variable P.A.S.																																																						
SCENIC II	SCENIC II	UCH																																																						
SCENIC II	SCENIC II	Airbag / Pretensioners																																																						
SCENIC II	SCENIC II	Air Conditioning																																																						
SCENIC II	SCENIC II	Instrument Panel																																																						
SCENIC II	SCENIC II	UPC																																																						
SCENIC II	SCENIC II	Parking Assistance																																																						
SCENIC II	SCENIC III	Injection																																																						
SCENIC II	SCENIC III	Automatic Gearbox																																																						
SCENIC II	SCENIC III	A.B.S.								V																																														
SCENIC II	SCENIC III	Instrument Panel																																																						
SCENIC II	SCENIC III	UCH																																																						
SCENIC II	SCENIC III	Airbag / Pretensioners																																																						
SCENIC II	SCENIC III	Air Conditioning																																																						
SCENIC II	SCENIC III	Parking Brake																																																						
SCENIC II	SCENIC III	UPC																																																						
THALIA/SYMBOL	THALIA/SYMBOL	Injection																																																						
THALIA/SYMBOL	THALIA/SYMBOL	A.B.S.																																																						
THALIA/SYMBOL	THALIA/SYMBOL	Immobilizer																																																						
THALIA/SYMBOL	THALIA/SYMBOL	Connection Unit																																																						
THALIA/SYMBOL	THALIA/SYMBOL	Airbag / Pretensioners								V																																														

Vehicle	System 1	System 2	Without boiler	Without passenger compartment heating resistor	Without power steering electric pump unit	Without thermoplungers	Write configuration	Write configuration [Flashing buzzer]	Write date new clutch fitted	Write Date of Last After Sales Operation	Write transmission oil change date	Write V.I.N	Originally fitted perimetric protection	De-ice function	Starter relay request	Illuminate hazard lamps upon impact	Raid function authorisation by diag	vehicle locked by autolock when driving	Timer courtesy light	Heated rear screen when driving	Airbag	Courtesy light timer	Key type	Second fitting alarm	Radio frequency function	Overspeed alarm for arabia	Engine type	Configuration privee 31	Interval variation with speed	Locking with key	Seat belt unfastened detection	Verrou logicel (software lock)	Central locking button type	Note Oil Wear Counter	With Swirl Flap	Oil Vapour Heater	Upstream Oxygen Sensor	Waste Gate Regulation	Stop And Start Function	Number Of Starting Cycles [RZ079]	Alternator Setpoint Voltage	Number Of Starting Cycles [VP343]	Configuration PRIVEE29	Air Flowmeter Programming	Adaptives On Air Intake Flap Fault	Particle Filter Pressure Diff. Sensor	Engine Adaptives [RZ002]	Engine Adaptives [RZ003]	Low Pressure EGR Valve Programming	Exhaust Flap Low Setting	High Pressure Pump Counter [RZ097]	Injection Pump Adaptatives [RZ077]	Injection Pump Adaptatives [RZ093]	Number Of Starting 1	Number Of Starting 2
THALIA/SYMBOL	THALIA/SYMBOL2	Injection																																																						
THALIA/SYMBOL	THALIA/SYMBOL2	A.B.S.								V																																														
THALIA/SYMBOL	THALIA/SYMBOL2	Variable P.A.S.								V																																														
THALIA/SYMBOL	THALIA/SYMBOL2	UCH																																																					
THALIA/SYMBOL	THALIA/SYMBOL2	Airbag / Pretensioners																																																					
TRAFIC II	TRAFIC II	Injection																																																					
TRAFIC II	TRAFIC II	A.B.S.								V																																													
TRAFIC II	TRAFIC II	Immobilizer																																																					
TRAFIC II	TRAFIC II	Connection Unit																																																					
TRAFIC II	TRAFIC II	Airbag / Pretensioners																																																					
TWINGO	TWINGO	Injection																																																					
TWINGO	TWINGO	A.B.S.																																																					
TWINGO	TWINGO	Immobilizer																																																					
TWINGO	TWINGO	Connection Unit																																																					
TWINGO	TWINGO	Airbag / Pretensioners								V																																													
MASTER	MASTER II PH1	Injection		V								V																																												
MASTER	MASTER II PH2	Injection		V								V																																												
MASTER	MASTER II PH3	Injection																																																					
MASTER	MASTER II PH3	Injection																																																					
MASTER	MASTER II PH3	Automatic Gearbox							V	V																																														
MASTER	MASTER II PH3	A.B.S.								V																																														
MASTER	MASTER II PH3	UCH																																																					
MASTER	MASTER II PH3	Airbag / Pretensioners								V																																														
MASTER	MASTER II PH3	TRACKER																																																					
MASTER	MASTER II PH3	Adaptation Unit																																																					
MASTER	MASTER II PH3	Suspension								V																																														
MASTER	MASTER II PH3	Parking Assistance																																																					
MASTER	MASTER III	Injection																																																					
MASTER	MASTER III	A.B.S.								V																																														
MASTER	MASTER III	Instrument Panel																																																					
MASTER	MASTER III	UCH																																																					
MASTER	MASTER III	Airbag / Pretensioners																																																					
MASTER	MASTER III	Air Conditioning																																																					
MASTER	MASTER III	UPC																																																					
LATITUDE	LATITUDE	Injection																																																					
LATITUDE	LATITUDE	A.B.S.								V																																													
LATITUDE	LATITUDE	Instrument panel					V																																																
LATITUDE	LATITUDE	UCH																																																					
LATITUDE	LATITUDE	Airbag / Pretensioners					V																																																
LATITUDE	LATITUDE	Air Conditioning																																																					
LATITUDE	LATITUDE	Parking brake																																																					
LATITUDE	LATITUDE	UPC																																																					

Vehicle	System 1	System 2	Without boiler	Without passenger compartment heating resistor	Without power steering electric pump unit	Without thermoplungers	Write configuration	Write configuration [Flashing buzzer]	Write date new clutch fitted	Write Date of Last After Sales Operation	Write transmission oil change date	Write V.I.N	Originally fitted perimetric protection	De-ice function	Starter relay request	Illuminate hazard lamps upon impact	Raid function authorisation by diag	vehicle locked by autolock when driving	Timer courtesy light	Heated rear screen when driving	Airbag	Courtesy light timer	Key type	Second fitting alarm	Radio frequency function	Overspeed alarm for arabia	Engine type	Configuration privee 31	Interval variation with speed	Locking with key	Seat belt unfastened detection	Verrou logicel (software lock)	Central locking button type	Note Oil Wear Counter	With Swirl Flap	Oil Vapour Heater	Upstream Oxygen Sensor	Waste Gate Regulation	Stop And Start Function	Number Of Starting Cycles [RZ079]	Alternator Setpoint Voltage	Number Of Starting Cycles [VP343]	Configuration PRIVEE29	Air Flowmeter Programming	Adaptives On Air Intake Flap Fault	Particle Filter Pressure Diff. Sensor	Engine Adaptives [RZ002]	Engine Adaptives [RZ003]	Low Pressure EGR Valve Programming	Exhaust Flap Low Setting	High Pressure Pump Counter [RZ097]	Injection Pump Adaptatives [RZ077]	Injection Pump Adaptatives [RZ093]	Number Of Starting 1	Number Of Starting 2
LATITUDE	LATITUDE	Parking Assistance																																																				
LATITUDE	LATITUDE	Driver's door																																																				
LATITUDE	LATITUDE	Passenger's door																																																				
LATITUDE	LATITUDE	Seat memory																																																				
LATITUDE	LATITUDE	Variable P.A.S.																																																				
DUSTER	DUSTER	Injection																																																				
DUSTER	DUSTER	Automatic Gearbox								V	V																																											
DUSTER	DUSTER	4 Wheel Drive					V																																															
DUSTER	DUSTER	Radio								V																																												
DUSTER	DUSTER	A.B.S.								V																																												
DUSTER	DUSTER	UCH						V																																														
DUSTER	DUSTER	Airbag / Pretensioners																																																				
DUSTER	DUSTER	Variable P.A.S.								V																																												
DUSTER	DUSTER PH2	Injection										V																										V	V	V	V		V	V	V	V	V	V	V	V	V	V	V	V	V
DUSTER	DUSTER PH2	A.B.S.								V		V																																										
DUSTER	DUSTER PH2	Instrument Panel																																																				
DUSTER	DUSTER PH2	UCH					V					V																																										
DUSTER	DUSTER PH2	Airbag / Pretensioners																																																				
DUSTER	DUSTER PH2	Variable P.A.S.								V		V																																										
DOKKER	DOKKER	Injection										V																											V	V	V							V			V	V	V		
DOKKER	DOKKER	A.B.S.								V		V																																										
DOKKER	DOKKER	Instrument Panel																																																				
DOKKER	DOKKER	UCH					V					V																												V											V				
DOKKER	DOKKER	Airbag / Pretensioners																																																				
DOKKER	DOKKER	Variable P.A.S.								V		V																																										

Vehicle	System 1	System 2	Number Of Starting 3	Number Of Starting 4	Number of Starting Cycle [VP343]	High Pressure Pump Counter [VP344]	Flywheel Target Programming [RZ037]	Flywheel Target Programming [RZ061]	Starter Adaptatives	Injection Time Programming	EGR Bypass Programming	Cylinder 1 Injector Code	Cylinder 2 Injector Code	Cylinder 3 Injector Code	Cylinder 4 Injector Code	Speedo index	Hill Start	Bleed rear R/H wheel	Bleed rear L/H wheel	Bleed front R/H wheel	Bleed front L/H wheel	R/H Rear Wheel Solenoid Valves	L/H Rear Wheel Solenoid Valves	R/H Front Wheel Solenoid Valves	L/H Front Wheel Solenoid Valves	Language Version	ADAC Display Type	Odometer in Km	Odometer in Miles	Hazard Warning Lights Illumination by ABS	Second Fitting Alarm	Alarm	Vehicle Type	Gearbox Type	Fuel Type	Trajectory Control	Tyre Pressure Monitoring	Distance Units	Overspeed Function - Ariabia	Lights Automatic Illumination	Particle Filter	Fuel Sender Calibration (Europe)	Fuel Sender Calibration (DOI)	Steering wheel angle sensor programming	Overspeed Alarm	Seat Belt Warning Module	Personalised oil change Frequency	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	Distance Before Next Oil Change Configuration	Mode Number	Static Test	Vacuum Pump Operation Request
CLIO	CLIO II	Injection																																																					
CLIO	CLIO II	A.B.S.																																																					
CLIO	CLIO II	Variable P.A.S.																																																					
CLIO	CLIO II	Immobilizer																																																					
CLIO	CLIO II	Connection Unit																																																					
CLIO	CLIO II	Airbag / Pretensioners																																																					
CLIO	CLIO II	Air Conditioning																																																					
CLIO	CLIO II	Discharge Lamp																																																					
CLIO	CLIO III	Injection																																																					
CLIO	CLIO III	A.B.S.																																																					
CLIO	CLIO III	Variable P.A.S.																																																					
CLIO	CLIO III	UCH																																																					
CLIO	CLIO III	Airbag / Pretensioners																																																					
CLIO	CLIO III	Instrument Panel																																																					
CLIO	CLIO III	UPC																																																					
CLIO	CLIO IV	Injection	V	V	V	V	V	V	V	V	V	V	V	V	V																																									
CLIO	CLIO IV	A.B.S.														V	V	V	V	V	V	V	V	V	V																														
CLIO	CLIO IV	Instrument panel																								V	V	V	V																										
CLIO	CLIO IV	UCH																												V	V	V																							
CLIO	CLIO IV	Airbag / Pretensioners																																																					
CLIO	CLIO IV	Air Conditioning																																																					
CLIO	CLIO IV	Automatic Gearbox																																																					
CLIO	CLIO IV	Variable P.A.S.																																																					
CLIO	CLIO IV	UPC																																																					
CLIO	CLIO IV	Parking Prox Can(AAP)																																																					
CLIO	CLIO IV	Telematic CTRL unit (TCU)																																																					
CLIO	CLIO IV	Hands-free module (HFM)																																																					
MODUS	MODUS	Injection																																																					
MODUS	MODUS	A.B.S.														V																																							
MODUS	MODUS	Instrument Panel																								V	V						V	V	V	V	V	V	V	V	V	V	V											
MODUS	MODUS	UCH																																																					
MODUS	MODUS	Airbag / Pretensioners																																																					
MODUS	MODUS	Variable P.A.S.																																											V										
MODUS	MODUS	UPC																																																					
FLUENCE	FLUENCE	Injection																V	V	V	V	V	V	V	V																														
FLUENCE	FLUENCE	Automatic Gearbox																																																					
FLUENCE	FLUENCE	A.B.S.																																																					
FLUENCE	FLUENCE	Variable P.A.S.																																																					
FLUENCE	FLUENCE	UCH																																																					
FLUENCE	FLUENCE	Airbag / Pretensioners																																																					
FLUENCE	FLUENCE	Air Conditioning																																																					
FLUENCE	FLUENCE	Instrument Panel																																																					

Vehicle	System 1	System 2	Number Of Starting 3	Number Of Starting 4	Number of Starting Cycle [VP343]	High Pressure Pump Counter [VP344]	Flywheel Target Programming [RZ037]	Flywheel Target Programming [RZ061]	Starter Adaptatives	Injection Time Programming	EGR Bypass Programming	Cylinder 1 Injector Code	Cylinder 2 Injector Code	Cylinder 3 Injector Code	Cylinder 4 Injector Code	Speedo index	Hill Start	Bleed rear R/H wheel	Bleed rear L/H wheel	Bleed front R/H wheel	Bleed front L/H wheel	R/H Rear Wheel Solenoid Valves	L/H Rear Wheel Solenoid Valves	R/H Front Wheel Solenoid Valves	L/H Front Wheel Solenoid Valves	Language Version	ADAC Display Type	Odometer in Km	Odometer in Miles	Hazard Warning Lights Illumination by ABS	Second Fitting Alarm	Alarm	Vehicle Type	Gearbox Type	Fuel Type	Trajectory Control	Tyre Pressure Monitoring	Distance Units	Overspeed Function - Ariabia	Lights Automatic Illumination	Particle Filter	Fuel Sender Calibration (Europe)	Fuel Sender Calibration (DOI)	Steering wheel angle sensor programming	Overspeed Alarm	Seat Belt Warning Module	Personalised oil change Frequency	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	Distance Before Next Oil Change Configuration	Mode Number	Static Test	Vacuum Pump Operation Request
FLUENCE	FLUENCE	UPC																																																			
FLUENCE	FLUENCE	Sunroof																																																			
FLUENCE	FLUENCE	Parking aid																																																			
FLUENCE	FLUENCE	Driver's door																																																			
KANGOO	KANGOO	Injection																																																			
KANGOO	KANGOO	A.B.S.																																																			
KANGOO	KANGOO	Immobilizer																																																			
KANGOO	KANGOO	Connection Unit																																																			
KANGOO	KANGOO	Airbag / Pretensioners																																																			
KANGOO	KANGOO MUX	Injection																																																			
KANGOO	KANGOO MUX	Immobilizer																																																			
KANGOO	KANGOO MUX	Connection Unit																																																			
KANGOO	KANGOO MUX	Airbag / Pretensioners																																																			
KANGOO	KANGOO II	Injection																																																			
KANGOO	KANGOO II	A.B.S.																																																			
KANGOO	KANGOO II	Instrument Panel																								V	V							V		V	V							V	V	V	V	V	V	V	V			
KANGOO	KANGOO II	Immobilizer																																																			
KANGOO	KANGOO II	Airbag / Pretensioners																																																			
KANGOO	KANGOO II	Variable P.A.S.																																										V								V		
KANGOO	KANGOO II	UPC																																																			
KANGOO	KANGOO PH2	Injection																																																		V	V
KANGOO	KANGOO PH2	Instrument Panel																								V	V							V			V							V	V	V							
KANGOO	KANGOO PH2	UCH																																																			
KANGOO	KANGOO PH2	Airbag / Pretensioners																																																			
KANGOO	KANGOO PH2	Automatic Gearbox																																																			
KANGOO	KANGOO PH2	Variable P.A.S.																																																			
KOLEOS	KOLEOS	Injection																																																			
KOLEOS	KOLEOS	Automatic Gearbox																																																			
KOLEOS	KOLEOS	A.B.S.																																																			
KOLEOS	KOLEOS	Variable P.A.S.																																																			
KOLEOS	KOLEOS	UCH																																																			
KOLEOS	KOLEOS	Airbag / Pretensioners																																																			
KOLEOS	KOLEOS	Instrument Panel																																																			
KOLEOS	KOLEOS	UPC																																																			
KOLEOS	KOLEOS	Tyres																																																			
KOLEOS	KOLEOS	Parking Assistance																																																			
KOLEOS	KOLEOS	Parking Brake																																																			
KOLEOS	KOLEOS	4 Wheel Drive																																																			
KOLEOS	KOLEOS	Radio																																																			
LAGUNA	LAGUNA II ph 2	Injection																																																			
LAGUNA	LAGUNA II ph 2	Automatic Gearbox																																																			
LAGUNA	LAGUNA II ph 2	A.B.S.																																																			

Vehicle	System 1	System 2	Number Of Starting 3	Number Of Starting 4	Number of Starting Cycle [VP343]	High Pressure Pump Counter [VP344]	Flywheel Target Programming [RZ037]	Flywheel Target Programming [RZ061]	Starter Adaptatives	Injection Time Programming	EGR Bypass Programming	Cylinder 1 Injector Code	Cylinder 2 Injector Code	Cylinder 3 Injector Code	Cylinder 4 Injector Code	Speedo index	Hill Start	Bleed rear R/H wheel	Bleed rear L/H wheel	Bleed front R/H wheel	Bleed front L/H wheel	R/H Rear Wheel Solenoid Valves	L/H Rear Wheel Solenoid Valves	R/H Front Wheel Solenoid Valves	L/H Front Wheel Solenoid Valves	Language Version	ADAC Display Type	Odometer in Km	Odometer in Miles	Hazard Warning Lights Illumination by ABS	Second Fitting Alarm	Alarm	Vehicle Type	Gearbox Type	Fuel Type	Trajectory Control	Tyre Pressure Monitoring	Distance Units	Overspeed Function - Ariabia	Lights Automatic Illumination	Particle Filter	Fuel Sender Calibration (Europe)	Fuel Sender Calibration (DOI)	Steering wheel angle sensor programming	Overspeed Alarm	Seat Belt Warning Module	Personalised oil change Frequency	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	Distance Before Next Oil Change Configuration	Mode Number	Static Test	Vacuum Pump Operation Request
LAGUNA	LAGUNA II ph 2	UCH																																																				
LAGUNA	LAGUNA II ph 2	Airbag / Pretensioners																																																				
LAGUNA	LAGUNA II ph 2	Air Conditioning																																																				
LAGUNA	LAGUNA II ph 2	Instrument Panel																																																				
LAGUNA	LAGUNA II ph 2	Parking brake																																																				
LAGUNA	LAGUNA III	Injection																																																				
LAGUNA	LAGUNA III	A.B.S.																																																				
LAGUNA	LAGUNA III	Instrument panel																																																				
LAGUNA	LAGUNA III	UCH																																																				
LAGUNA	LAGUNA III	Airbag / Pretensioners																																																				
LAGUNA	LAGUNA III	Air Conditioning																																																				
LAGUNA	LAGUNA III	Automatic Gearbox																																																				
LAGUNA	LAGUNA III	Parking brake																																																				
LAGUNA	LAGUNA III	UPC																																																				
LOGAN	LOGAN	Injection																																																				
LOGAN	LOGAN	GAS Injection																																																				
LOGAN	LOGAN	A.B.S.																																																				
LOGAN	LOGAN	Variable P.A.S.																																																				
LOGAN	LOGAN	UCH																																																				
LOGAN	LOGAN	Airbag / Pretensioners																																																				
LOGAN	LOGAN II	Injection	V	V	V	V			V	V	V	V	V	V	V																																								
LOGAN	LOGAN II	A.B.S.														V	V	V	V	V	V	V	V	V	V																														
LOGAN	LOGAN II	Instrument Panel																																																				
LOGAN	LOGAN II	UCH																												V	V	V																							
LOGAN	LOGAN II	Airbag / Pretensioners																																																				
LOGAN	LOGAN II	Air Conditioning																																																				
LOGAN	LOGAN II	Variable P.A.S.																																																				
MEGANE	MEGANE	Injection																																																				
MEGANE	MEGANE	A.B.S.																																																				
MEGANE	MEGANE	Immobilizer																																																				
MEGANE	MEGANE	Connection Unit																																																				
MEGANE	MEGANE	Airbag / Pretensioners																																																				
MEGANE	MEGANE II	Injection																																																				
MEGANE	MEGANE II	Automatic Gearbox																																																				
MEGANE	MEGANE II	A.B.S.																																																				
MEGANE	MEGANE II	Variable P.A.S.																																																				
MEGANE	MEGANE II	UCH																																																				
MEGANE	MEGANE II	Airbag / Pretensioners																																																				
MEGANE	MEGANE II	Air Conditioning																																																				
MEGANE	MEGANE II	Instrument Panel																																																				
MEGANE	MEGANE II	UPC																																																				
MEGANE	MEGANE III	Injection																																																				

Vehicle	System 1	System 2	Number Of Starting 3	Number Of Starting 4	Number of Starting Cycle [VP343]	High Pressure Pump Counter [VP344]	Flywheel Target Programming [RZ037]	Flywheel Target Programming [RZ061]	Starter Adaptatives	Injection Time Programming	EGR Bypass Programming	Cylinder 1 Injector Code	Cylinder 2 Injector Code	Cylinder 3 Injector Code	Cylinder 4 Injector Code	Speedo index	Hill Start	Bleed rear R/H wheel	Bleed rear L/H wheel	Bleed front R/H wheel	Bleed front L/H wheel	R/H Rear Wheel Solenoid Valves	L/H Rear Wheel Solenoid Valves	R/H Front Wheel Solenoid Valves	L/H Front Wheel Solenoid Valves	Language Version	ADAC Display Type	Odometer in Km	Odometer in Miles	Hazard Warning Lights Illumination by ABS	Second Fitting Alarm	Alarm	Vehicle Type	Gearbox Type	Fuel Type	Trajectory Control	Tyre Pressure Monitoring	Distance Units	Overspeed Function - Ariabia	Lights Automatic Illumination	Particle Filter	Fuel Sender Calibration (Europe)	Fuel Sender Calibration (DOI)	Steering wheel angle sensor programming	Overspeed Alarm	Seat Belt Warning Module	Personalised oil change Frequency	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	Distance Before Next Oil Change Configuration	Mode Number	Static Test	Vacuum Pump Operation Request
MEGANE	MEGANE III	Automatic Gearbox																																																				
MEGANE	MEGANE III	A.B.S.																																																				
MEGANE	MEGANE III	Instrument Panel																																																				
MEGANE	MEGANE III	UCH																																																				
MEGANE	MEGANE III	Airbag / Pretensioners																																																				
MEGANE	MEGANE III	Air Conditioning																																																				
MEGANE	MEGANE III	Parking Brake																																																				
MEGANE	MEGANE III	UPC																																																				
SANDERO	SANDERO	Injection																																																				
SANDERO	SANDERO	GAS Injection																																																				
SANDERO	SANDERO	A.B.S.																																																				
SANDERO	SANDERO	Variable P.A.S.																																																				
SANDERO	SANDERO	UCH																																																				
SANDERO	SANDERO	Airbag / Pretensioners																																																				
SCENIC II	SCENIC	Injection																																																				
SCENIC II	SCENIC	A.B.S.																																																				
SCENIC II	SCENIC	Immobilizer																																																				
SCENIC II	SCENIC	Connection Unit																																																				
SCENIC II	SCENIC	Airbag / Pretensioners																																																				
SCENIC II	SCENIC II	Injection																																																				
SCENIC II	SCENIC II	A.B.S.																																																				
SCENIC II	SCENIC II	Variable P.A.S.																																																				
SCENIC II	SCENIC II	UCH																																																				
SCENIC II	SCENIC II	Airbag / Pretensioners																																																				
SCENIC II	SCENIC II	Air Conditioning																																																				
SCENIC II	SCENIC II	Instrument Panel																																																				
SCENIC II	SCENIC II	UPC																																																				
SCENIC II	SCENIC II	Parking Assistance																																																				
SCENIC II	SCENIC III	Injection																																																				
SCENIC II	SCENIC III	Automatic Gearbox																																																				
SCENIC II	SCENIC III	A.B.S.																																																				
SCENIC II	SCENIC III	Instrument Panel																																																				
SCENIC II	SCENIC III	UCH																																																				
SCENIC II	SCENIC III	Airbag / Pretensioners																																																				
SCENIC II	SCENIC III	Air Conditioning																																																				
SCENIC II	SCENIC III	Parking Brake																																																				
SCENIC II	SCENIC III	UPC																																																				
THALIA/SYMBOL	THALIA/SYMBOL	Injection																																																				
THALIA/SYMBOL	THALIA/SYMBOL	A.B.S.																																																				
THALIA/SYMBOL	THALIA/SYMBOL	Immobilizer																																																				
THALIA/SYMBOL	THALIA/SYMBOL	Connection Unit																																																				
THALIA/SYMBOL	THALIA/SYMBOL	Airbag / Pretensioners																																																				

Vehicle	System 1	System 2	Number Of Starting 3	Number Of Starting 4	Number of Starting Cycle [VP343]	High Pressure Pump Counter [VP344]	Flywheel Target Programming [RZ037]	Flywheel Target Programming [RZ061]	Starter Adaptatives	Injection Time Programming	EGR Bypass Programming	Cylinder 1 Injector Code	Cylinder 2 Injector Code	Cylinder 3 Injector Code	Cylinder 4 Injector Code	Speedo index	Hill Start	Bleed rear R/H wheel	Bleed rear L/H wheel	Bleed front R/H wheel	Bleed front L/H wheel	R/H Rear Wheel Solenoid Valves	L/H Rear Wheel Solenoid Valves	R/H Front Wheel Solenoid Valves	L/H Front Wheel Solenoid Valves	Language Version	ADAC Display Type	Odometer in Km	Odometer in Miles	Hazard Warning Lights Illumination by ABS	Second Fitting Alarm	Alarm	Vehicle Type	Gearbox Type	Fuel Type	Trajectory Control	Tyre Pressure Monitoring	Distance Units	Overspeed Function - Ariabia	Lights Automatic Illumination	Particle Filter	Fuel Sender Calibration (Europe)	Fuel Sender Calibration (DOI)	Steering wheel angle sensor programming	Overspeed Alarm	Seat Belt Warning Module	Personalised oil change Frequency	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	Distance Before Next Oil Change Configuration	Mode Number	Static Test	Vacuum Pump Operation Request
THALIA/SYMBOL	THALIA/SYMBOL2	Injection																																																				
THALIA/SYMBOL	THALIA/SYMBOL2	A.B.S.																																																				
THALIA/SYMBOL	THALIA/SYMBOL2	Variable P.A.S.																																																				
THALIA/SYMBOL	THALIA/SYMBOL2	UCH																																																				
THALIA/SYMBOL	THALIA/SYMBOL2	Airbag / Pretensioners																																																				
TRAFIC II	TRAFIC II	Injection																																																				
TRAFIC II	TRAFIC II	A.B.S.																																																				
TRAFIC II	TRAFIC II	Immobilizer																																																				
TRAFIC II	TRAFIC II	Connection Unit																																																				
TRAFIC II	TRAFIC II	Airbag / Pretensioners																																																				
TWINGO	TWINGO	Injection																																																				
TWINGO	TWINGO	A.B.S.																																																				
TWINGO	TWINGO	Immobilizer																																																				
TWINGO	TWINGO	Connection Unit																																																				
TWINGO	TWINGO	Airbag / Pretensioners																																																				
MASTER	MASTER II PH1	Injection																																																				
MASTER	MASTER II PH2	Injection																																																				
MASTER	MASTER II PH3	Injection																																																				
MASTER	MASTER II PH3	Injection																																																				
MASTER	MASTER II PH3	Automatic Gearbox																																																				
MASTER	MASTER II PH3	A.B.S.																																																				
MASTER	MASTER II PH3	UCH																																																				
MASTER	MASTER II PH3	Airbag / Pretensioners																																																				
MASTER	MASTER II PH3	TRACKER																																																				
MASTER	MASTER II PH3	Adaptation Unit																																																				
MASTER	MASTER II PH3	Suspension																																																				
MASTER	MASTER II PH3	Parking Assistance																																																				
MASTER	MASTER III	Injection																																																				
MASTER	MASTER III	A.B.S.																																																				
MASTER	MASTER III	Instrument Panel																																																				
MASTER	MASTER III	UCH																																																				
MASTER	MASTER III	Airbag / Pretensioners																																																				
MASTER	MASTER III	Air Conditioning																																																				
MASTER	MASTER III	UPC																																																				
LATITUDE	LATITUDE	Injection																																																				
LATITUDE	LATITUDE	A.B.S.																																																				
LATITUDE	LATITUDE	Instrument panel																																																				
LATITUDE	LATITUDE	UCH																																																				
LATITUDE	LATITUDE	Airbag / Pretensioners																																																				
LATITUDE	LATITUDE	Air Conditioning																																																				
LATITUDE	LATITUDE	Parking brake																																																				
LATITUDE	LATITUDE	UPC																																																				

Vehicle	System 1	System 2	Number Of Starting 3	Number Of Starting 4	Number of Starting Cycle [VP343]	High Pressure Pump Counter [VP344]	Flywheel Target Programming [RZ037]	Flywheel Target Programming [RZ061]	Starter Adaptatives	Injection Time Programming	EGR Bypass Programming	Cylinder 1 Injector Code	Cylinder 2 Injector Code	Cylinder 3 Injector Code	Cylinder 4 Injector Code	Speedo index	Hill Start	Bleed rear R/H wheel	Bleed rear L/H wheel	Bleed front R/H wheel	Bleed front L/H wheel	R/H Rear Wheel Solenoid Valves	L/H Rear Wheel Solenoid Valves	R/H Front Wheel Solenoid Valves	L/H Front Wheel Solenoid Valves	Language Version	ADAC Display Type	Odometer in Km	Odometer in Miles	Hazard Warning Lights Illumination by ABS	Second Fitting Alarm	Alarm	Vehicle Type	Gearbox Type	Fuel Type	Trajectory Control	Tyre Pressure Monitoring	Distance Units	Overspeed Function - Ariabia	Lights Automatic Illumination	Particle Filter	Fuel Sender Calibration (Europe)	Fuel Sender Calibration (DOI)	Steering wheel angle sensor programming	Overspeed Alarm	Seat Belt Warning Module	Personalised oil change Frequency	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	LCD Display Fuel Gauge Calibration	Analogic Display Fuel Gauge Calibration	Distance Before Next Oil Change Configuration	Mode Number	Static Test	Vacuum Pump Operation Request
LATITUDE	LATITUDE	Parking Assistance																																																				
LATITUDE	LATITUDE	Driver's door																																																				
LATITUDE	LATITUDE	Passenger's door																																																				
LATITUDE	LATITUDE	Seat memory																																																				
LATITUDE	LATITUDE	Variable P.A.S.																																																				
DUSTER	DUSTER	Injection																																																				
DUSTER	DUSTER	Automatic Gearbox																																																				
DUSTER	DUSTER	4 Wheel Drive																																																				
DUSTER	DUSTER	Radio																																																				
DUSTER	DUSTER	A.B.S.																																																				
DUSTER	DUSTER	UCH																																																				
DUSTER	DUSTER	Airbag / Pretensioners																																																				
DUSTER	DUSTER	Variable P.A.S.																																																				
DUSTER	DUSTER PH2	Injection	V	V	V	V	V	V	V	V	V	V	V	V	V			V	V	V	V	V	V	V	V																												V	V
DUSTER	DUSTER PH2	A.B.S.														V	V	V	V	V	V	V	V	V	V																													
DUSTER	DUSTER PH2	Instrument Panel																																																				
DUSTER	DUSTER PH2	UCH																												V	V	V																						
DUSTER	DUSTER PH2	Airbag / Pretensioners																																																				
DUSTER	DUSTER PH2	Variable P.A.S.																																																				
DOKKER	DOKKER	Injection			V	V	V	V																																														
DOKKER	DOKKER	A.B.S.														V	V	V	V	V	V	V	V	V	V																													
DOKKER	DOKKER	Instrument Panel																																																				
DOKKER	DOKKER	UCH																												V	V	V																						
DOKKER	DOKKER	Airbag / Pretensioners																																																				
DOKKER	DOKKER	Variable P.A.S.																																																				

Vehicle	System 1	System 2	DTC	CURR	ACT	ECU Information Display	Initial Autoadaptive Configuration	Auto Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	TEVES MK20 Bleeding	TEVES MK20 Simulation	Learning keys and remote control	Initialisation of auto auto-adaptation	Read Configuration	Check Target Teeth	Bleed Hydraulic Unit and Braking Circuits	Lock Computer	Unlock Computer	[Write Config.]Drivers Front Airbag	[Write Config.]Passeengers Front Airbag	[Write Config.]D.F Thorax Side Airbag	[Write Config.]P.F Thorax Side Airbag	[Write Config.]D.F Buckle Belt Pretensioner	[Write Config.]P.F Buckle Belt Pretensioner	[Write Config.]D.F Side Impact Sensor	[Write Config.]P.F Side Impact Sensor	[Write Config.]D.Seat Buckle Sensor	[Write Config.]P.Airbag Warning Light	[Write Config.]Impact Info. Connect	[Write Config.]FL Hand Inertia Wheel	[Write Config.]FR Hand Inertia Wheel	[Write Config.]Seat Belt Light	[Write Config.]Belt Reminder Buzzer	[Write Config.]P.Airbag Lock Mode	[Write Config.]Side On(SteeringWheel)	[Write Configuration] Flashing Buzzer	Immobiliser	Lock Injector Control	Unlock Injector Control	Programmed Values	Bleed Hydraulic Unit and Braking Circuits	Configuration View Only	Language Configuration
Pride	ENGINE	SIEMENS (OLD)	V	V	V	V																																							
Pride	ENGINE	SIEMENS (NEW)	V	V	V	V																																							
Pride	ENGINE	VALEO	V	V	V	V																																							
Pride	ENGINE	S2000	V	V	V	V																																							
Pride	ENGINE	BOSCH	V	V	V	V																																							
Pride	ENGINE	BOSCH Bifuel CNG	V	V	V	V																																							
Pride	ENGINE	CNG SIEMENS	V	V	V	V																																							
Pride	ENGINE	SIEMENS EURO 4	V	V	V	V																																							
Pride	ABS	MANDO ABS	V	V	V	V																																							
Pride	ABS	BOSCH ABS	V	V	V	V																																							
Pride	SRS	Crouse	V		V	V																																							
Pride	SRS	Siemens ABG	V	V		V																																							
Pride	IMMOBILIZER	VALEO	V	V																																									
Pride	IMMOBILIZER	SIEMENS	V	V		V																																							
Pride	IMMOBILIZER	BOSCH	V	V		V																																							
Pride	IMMOBILIZER	Immobilizer CIM	V	V																																									
Nissan Vanet	ENGINE	SIEMENS EURO 4	V	V	V	V																																							
Tiba	ENGINE	SIEMENS EURO 4	V	V	V	V																																							
Tiba	ABS	MANDO ABS	V	V	V	V																																							
Tiba	ABS	BOSCH ABS	V	V	V	V																																							
Tiba	SRS	Crouse	V		V	V																																							
Tiba	SRS	Siemens ABG	V	V		V																																							
Tiba	IMMOBILIZER	VALEO	V	V																																									
Tiba	IMMOBILIZER	SIEMENS	V	V		V																																							
Tiba	IMMOBILIZER	BOSCH	V	V		V																																							
Tiba	IMMOBILIZER	Immobilizer CIM	V	V																																									
Citroen Xantia	Engine	Bosch MP 5.2	V	V	V	V																																							
Citroen Xantia	Engine	Bosch MP 7.3	V	V	V	V	V																																						
Citroen Xantia	Immobilizer	CPH	V	V	V	V																																							
Citroen Xantia	Active Safety	ABS TEVES MK20	V	V	V	V						V	V																																
Citroen Xantia	Airbag	Airbag Front	V		V	V																																							
Citroen Xantia	Airbag	Airbag Left	V			V																																							
Citroen Xantia	Airbag	Airbag Right	V			V																																							
Citroen C5	Gasoline Engine	5FZ SAGEM S2000 PM1	V	V	V	V																																							
Citroen C5	Gasoline Engine	6FZ SAGEM S2000	V	V	V	V	V	V	V																																				
Citroen C5	Gasoline Engine	RFN MM4.8P	V	V	V	V	V	V	V																																				
Citroen C5	Gasoline Engine	RLZ Siemens SIRIUS 81	V	V		V																																							
Citroen C5	Gasoline Engine	XFX Bosch ME7.4.6	V	V		V																																							
Citroen C5	Diesel Engine	4HX Bosch EDC15C3(C/RAIL)	V	V		V																																							
Citroen C5	Diesel Engine	RHY Bosch EDC15C2(C/RAIL)	V	V		V																																							
Citroen C5	Diesel Engine	RHY Siemens SID801(C/RL)	V	V		V																																							

Vehicle	System 1	System 2	DTC	CURR	ACT	ECU Information Display	Initial Autoadaptive Configuration	Auto Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	TEVES MK20 Bleeding	TEVES MK20 Simulation	Learning keys and remote control	Initialisation of auto auto-adaptation	Read Configuration	Check Target Teeth	Bleed Hydraulic Unit and Braking Circuits	Lock Computer	Unlock Computer	[Write Config.]Drivers Front Airbag	[Write Config.]Passeengers Front Airbag	[Write Config.]D.F Thorax Side Airbag	[Write Config.]P.F Thorax Side Airbag	[Write Config.]D.F Buckle Belt Pretensioner	[Write Config.]P.F Buckle Belt Pretensioner	[Write Config.]D.F Side Impact Sensor	[Write Config.]P.F Side Impact Sensor	[Write Config.]D.Seat Buckle Sensor	[Write Config.]P.Airbag Warning Light	[Write Config.]Impact Info. Connect	[Write Config.]FL Hand Inertia Wheel	[Write Config.]FR Hand Inertia Wheel	[Write Config.]Seat Belt Light	[Write Config.]Belt Reminder Buzzer	[Write Config.]P.Airbag Lock Mode	[Write Config.]Side On(SteeringWheel)	[Write Configuration] Flashing Buzzer	Immobiliser	Lock Injector Control	Unlock Injector Control	Programmed Values	Bleed Hydraulic Unit and Braking Circuits	Configuration View Only	Language Configuration
Citroen C5	Diesel Engine	RHZ Bosch EDC15C3(C/RAIL)	V	V		V																																							
Citroen C5	Automatic Transaxle	AL4 AT (FAST)	V	V		V																																							
Citroen C5	Automatic Transaxle	Auto GEAR 4HP20	V	V	V	V																																							
Citroen C5	Active Safety	ABS TEVES MK60	V	V		V																																							
Citroen C5	Airbag	Airbag SAC Central	V	V		V			V	V	V																																		
Citroen C5	Body	Auto PC	V	V	V	V																																							
Citroen C5	Body	Auto Radio	V	V	V	V																																							
Citroen C5	Body	CD Player	V	V	V	V																																							
Citroen C5	Body	Clim Regulee	V	V		V																																							
Citroen C5	Body	Control Panel	V	V	V	V																																							
Citroen C5	Body	Diesel Addtive Function	V	V		V																																							
Citroen C5	Body	Display SAGEM A	V	V	V	V																																							
Citroen C5	Body	Display Siemens B	V	V	V	V																																							
Citroen C5	Body	Display Siemens C	V	V	V	V																																							
Citroen C5	Body	Display VDO D	V	V	V	V																																							
Citroen C5	Body	LH HEADLAMP	V	V		V																																							
Citroen C5	Body	Navigation	V	V		V																																							
Citroen C5	Body	Parking Assitance	V	V	V	V																																							
Citroen C5	Body	RH HEADLAMP	V	V		V																																							
Citroen C5	Body	SUNROOF	V	V		V																																							
Citroen C5	Body	Telemat	V	V		V																																							
Citroen C5	Body		V	V	V	V																																							
Citroen C5	Chassis	SUSPENSION	V	V		V																																							
Citroen C5	Security	Built-In System Interface	V	V	V	V	V	V	V																																				
Citroen C5R	Security	Built-in systems interface	V	V	V	V																																							
Citroen C5R	Injection		V	V	V	V									V																														
Citroen C5R	Gearbox ECU		V	V	V	V																																							
Citroen C5R	Anti-lock brake system		V	V	V	V																																							
Citroen C5R	Instrument panel		V	V	V	V																																							
Citroen C5R	Radio		V	V	V	V																																							
Citroen C5R	CD Player		V	V	V	V																																							
Citroen C5R	Parking aid		V	V	V	V																																							
Citroen C5R	Air conditioning		V	V	V	V																																							
Citroen C5R	Switch module under the steering wheel		V	V	V	V																																							
Citroen C5R	Driver's door module		V	V	V	V																																							
Citroen C5R	Passenger's door module		V	V	V	V																																							
Citroen C5R	Rain sensor / Brightness		V			V																																							
Citroen C5R	Sun roof		V	V	V	V																																							
Citroen C5R	Airbag		V	V		V																																							
Citroen C5R	Suspension		V	V		V																																							
Citroen C5R	Power steering		V	V	V	V																																							

Vehicle	System 1	System 2	DTC	CURR	ACT	ECU Information Display	Initial Autoadaptive Configuration	Auto Configuration	Airbag Configuration	Airbag Lock	Airbag Unlock	TEVES MK20 Bleeding	TEVES MK20 Simulation	Learning keys and remote control	Initialisation of auto auto-adaptation	Read Configuration	Check Target Teeth	Bleed Hydraulic Unit and Braking Circuits	Lock Computer	Unlock Computer	[Write Config.]Drivers Front Airbag	[Write Config.]Passeengers Front Airbag	[Write Config.]D.F Thorax Side Airbag	[Write Config.]P.F Thorax Side Airbag	[Write Config.]D.F Buckle Belt Pretensioner	[Write Config.]P.F Buckle Belt Pretensioner	[Write Config.]D.F Side Impact Sensor	[Write Config.]P.F Side Impact Sensor	[Write Config.]D.Seat Buckle Sensor	[Write Config.]P.Airbag Warning Light	[Write Config.]Impact Info. Connect	[Write Config.]FL Hand Inertia Wheel	[Write Config.]FR Hand Inertia Wheel	[Write Config.]Seat Belt Light	[Write Config.]Belt Reminder Buzzer	[Write Config.]P.Airbag Lock Mode	[Write Config.]Side On(SteeringWheel)	[Write Configuration] Flashing Buzzer	Immobiliser	Lock Injector Control	Unlock Injector Control	Programmed Values	Bleed Hydraulic Unit and Braking Circuits	Configuration View Only	Language Configuration
Citroen C5R	Multifunction		V	V	V	V																																							
Citroen C5 (X7)	Engine		V	V	V	V									V																														
Citroen C5 (X7)	Auto gearbox		V	V	V	V																																							
Citroen C5 (X7)	Anti-lock brake system		V	V	V	V																																							
Citroen C5 (X7)	Built-in systems interface		V	V	V	V																																							
Citroen C5 (X7)	Switch module under the steering wheel		V	V	V	V																																							
Citroen C5 (X7)	Airbag		V	V		V																																							
Citroen C5 (X7)	Rain sensor / Brightness		V			V																																							
Citroen C5 (X7)	Driver's door module		V	V	V	V																																							
Citroen C5 (X7)	Passenger's door module		V	V	V	V																																							
Citroen C5 (X7)	Parking aid		V	V	V	V																																							
Citroen C5 (X7)	Instrument panel		V	V	V	V																																							
Citroen C5 (X7)	Radio		V	V	V	V																																							
Citroen C5 (X7)	Multifunction		V	V	V	V																																							
Citroen C5 (X7)	Air conditioning		V	V	V	V																																							
Tondar 90	Injection		V	V	V	V										V																													
Tondar 90	Injection		V	V	V	V										V																													
Tondar 90	GAS Injection		V	V	V	V										V																													
Tondar 90	A.B.S.		V	V	V	V											V	V																											
Tondar 90	Airbag / Pretensioners		V	V	-	V										V			V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V							
Tondar 90	UCH		V	V	V	V										V																													
MEGANE II	Injection		V	V	V	V										V																							V	V	V				
MEGANE II	Injection		V	V	V	V										V																							V	V	V				
MEGANE II	Automatic Gearbox		V	V		V																																							
MEGANE II	A.B.S.		V	V	V	V																																				V			
MEGANE II	Variable P.A.S.		V	V		V																																							
MEGANE II	Airbag / Pretensioners		V	V		V										V			V	V																									
MEGANE II	Airbag / Pretensioners		V	V		V										V			V	V																									
MEGANE II	Instrument Panel		V	V	V	V																																					V	V
MEGANE II	Air Conditioning		V	V		V		V																																					
MEGANE II	UPC		V	V	V	V																																							
MEGANE II	UCH		V	V	V	V										V																													
Nissan Pickup	Engine	Diesel	V	V	V	V																																							
Nissan Pickup	Engine	Bosch 7.9.7.1	V	V	V	V																																							
Z300	ENGINE		V	V	V	V																																							
Z300	IMMOBILIZER		V	V		V																																							
Special Function	ECU Reset		V																																										

Vehicle	System 1	System 2	Bodywork Type	Gearbox Type	Consumption Measurement Units	Vehicle Speed Signal Transmitter	Tyre pressure Monitoring	Distance Units	Cruise Control / Speed Limiter	Overspeed Function - Arabia	Reserve Capacity	Lights Automatic Illumination	Card/Key	Rhestat Presence	Clock	Seat Belt Reminder Buzzer	Particle Filter	Reset Adaptaion Value	ICU Change Coding	ECM Change Coding	Valeo Immobilizer Coding	Change Key Coding	ICU Reset	ECM Reset	ICU Change	ECM Change	Immo. Key Coding	Initialising the autoadaptives	ECM ICU and Key Learning	ECM Neutralizing	ICU Neutralizing	ECU Reset	Input Safety Code	Set Safety Code	Read immobilizer to EMS	Read EMS to immobilizer	Key learning	Key erasing	Immobilizer reset	EMS reset
Pride	ENGINE	SIEMENS (OLD)																V																						
Pride	ENGINE	SIEMENS (NEW)																V																						
Pride	ENGINE	VALEO																																						
Pride	ENGINE	S2000																																						
Pride	ENGINE	BOSCH																																						
Pride	ENGINE	BOSCH Bifuel CNG																																						
Pride	ENGINE	CNG SIEMENS																																						
Pride	ENGINE	SIEMENS EURO 4																																						
Pride	ABS	MANDO ABS																																						
Pride	ABS	BOSCH ABS																																						
Pride	SRS	Crouse																																						
Pride	SRS	Siemens ABG																																						
Pride	IMMOBILIZER	VALEO																	V	V	V	V																		
Pride	IMMOBILIZER	SIEMENS																					V	V	V	V	V													
Pride	IMMOBILIZER	BOSCH																																						
Pride	IMMOBILIZER	Immobilizer CIM																											V	V	V									
Nissan Vanet	ENGINE	SIEMENS EURO 4																																						
Tiba	ENGINE	SIEMENS EURO 4																																						
Tiba	ABS	MANDO ABS																																						
Tiba	ABS	BOSCH ABS																																						
Tiba	SRS	Crouse																																						
Tiba	SRS	Siemens ABG																																						
Tiba	IMMOBILIZER	VALEO																	V	V	V	V																		
Tiba	IMMOBILIZER	SIEMENS																					V	V	V	V	V													
Tiba	IMMOBILIZER	BOSCH																																						
Tiba	IMMOBILIZER	Immobilizer CIM																											V	V	V									
Citroen Xantia	Engine	Bosch MP 5.2																																						
Citroen Xantia	Engine	Bosch MP 7.3																																						
Citroen Xantia	Immobilizer	CPH																																						
Citroen Xantia	Active Safety	ABS TEVES MK20																																						
Citroen Xantia	Airbag	Airbag Front																																						
Citroen Xantia	Airbag	Airbag Left																																						
Citroen Xantia	Airbag	Airbag Right																																						
Citroen C5	Gasoline Engine	5FZ SAGEM S2000 PM1																																						
Citroen C5	Gasoline Engine	6FZ SAGEM S2000																																						
Citroen C5	Gasoline Engine	RFN MM4.8P																																						
Citroen C5	Gasoline Engine	RLZ Siemens SIRIUS 81																																						
Citroen C5	Gasoline Engine	XFX Bosch ME7.4.6																																						
Citroen C5	Diesel Engine	4HX Bosch EDC15C3(C/RAIL)																																						
Citroen C5	Diesel Engine	RHY Bosch EDC15C2(C/RAIL)																																						
Citroen C5	Diesel Engine	RHY Siemens SID801(C/RL)																																						

Vehicle	System 1	System 2	Bodywork Type	Gearbox Type	Consumption Measurement Units	Vehicle Speed Signal Transmitter	Tyre pressure Monitoring	Distance Units	Cruise Control / Speed Limiter	Overspeed Function - Arabia	Reserve Capacity	Lights Automatic Illumination	Card/Key	Rhestat Presence	Clock	Seat Belt Reminder Buzzer	Particle Filter	Reset Adaptaion Value	ICU Change Coding	ECM Change Coding	Valeo Immobilizer Coding	Change Key Coding	ICU Reset	ECM Reset	ICU Change	ECM Change	Immo. Key Coding	Initialising the autoadaptives	ECM ICU and Key Learning	ECM Neutralizing	ICU Neutralizing	ECU Reset	Input Safety Code	Set Safety Code	Read immobilizer to EMS	Read EMS to immobilizer	Key learning	Key erasing	Immobilizer reset	EMS reset
Citroen C5	Diesel Engine	RHZ Bosch EDC15C3(C/RAIL)																																						
Citroen C5	Automatic Transaxle	AL4 AT (FAST)																																						
Citroen C5	Automatic Transaxle	Auto GEAR 4HP20																																						
Citroen C5	Active Safety	ABS TEVES MK60																																						
Citroen C5	Airbag	Airbag SAC Central																																						
Citroen C5	Body	Auto PC																																						
Citroen C5	Body	Auto Radio																																						
Citroen C5	Body	CD Player																																						
Citroen C5	Body	Clim Regulee																																						
Citroen C5	Body	Control Panel																																						
Citroen C5	Body	Diesel Addtive Function																																						
Citroen C5	Body	Display SAGEM A																																						
Citroen C5	Body	Display Siemens B																																						
Citroen C5	Body	Display Siemens C																																						
Citroen C5	Body	Display VDO D																																						
Citroen C5	Body	LH HEADLAMP																																						
Citroen C5	Body	Navigation																																						
Citroen C5	Body	Parking Assitance																																						
Citroen C5	Body	RH HEADLAMP																																						
Citroen C5	Body	SUNROOF																																						
Citroen C5	Body	Telemat																																						
Citroen C5	Body																																							
Citroen C5	Chassis	SUSPENSION																																						
Citroen C5	Security	Built-In System Interface																																						
Citroen C5R	Security	Built-in systems interface																																						
Citroen C5R	Injection																																							
Citroen C5R	Gearbox ECU																																							
Citroen C5R	Anti-lock brake system																																							
Citroen C5R	Instrument panel																																							
Citroen C5R	Radio																																							
Citroen C5R	CD Player																																							
Citroen C5R	Parking aid																																							
Citroen C5R	Air conditioning																																							
Citroen C5R	Switch module under the steering wheel																																							
Citroen C5R	Driver's door module																																							
Citroen C5R	Passenger's door module																																							
Citroen C5R	Rain sensor / Brightness																																							
Citroen C5R	Sun roof																																							
Citroen C5R	Airbag																																							
Citroen C5R	Suspension																																							
Citroen C5R	Power steering																																							

Vehicle	System 1	System 2	Bodywork Type	Gearbox Type	Consumption Measurement Units	Vehicle Speed Signal Transmitter	Tyre pressure Monitoring	Distance Units	Cruise Control / Speed Limiter	Overspeed Function - Arabia	Reserve Capacity	Lights Automatic Illumination	Card/Key	Rhestat Presence	Clock	Seat Belt Reminder Buzzer	Particle Filter	Reset Adaptaion Value	ICU Change Coding	ECM Change Coding	Valeo Immobilizer Coding	Change Key Coding	ICU Reset	ECM Reset	ICU Change	ECM Change	Immo. Key Coding	Initialising the autoadaptives	ECM ICU and Key Learning	ECM Neutralizing	ICU Neutralizing	ECU Reset	Input Safety Code	Set Safety Code	Read immobilizer to EMS	Read EMS to immobilizer	Key learning	Key erasing	Immobilizer reset	EMS reset
Citroen C5R	Multifunction																																							
Citroen C5 (X7)	Engine																																							
Citroen C5 (X7)	Auto gearbox																																							
Citroen C5 (X7)	Anti-lock brake system																																							
Citroen C5 (X7)	Built-in systems interface																																							
Citroen C5 (X7)	Switch module under the steering wheel																																							
Citroen C5 (X7)	Airbag																																							
Citroen C5 (X7)	Rain sensor / Brightness																																							
Citroen C5 (X7)	Driver's door module																																							
Citroen C5 (X7)	Passenger's door module																																							
Citroen C5 (X7)	Parking aid																																							
Citroen C5 (X7)	Instrument panel																																							
Citroen C5 (X7)	Radio																																							
Citroen C5 (X7)	Multifunction																																							
Citroen C5 (X7)	Air conditioning																																							
Tondar 90	Injection																																							
Tondar 90	Injection																																							
Tondar 90	GAS Injection																																							
Tondar 90	A.B.S.																																							
Tondar 90	Airbag / Pretensioners																																							
Tondar 90	UCH																																							
MEGANE II	Injection																																							
MEGANE II	Injection																																							
MEGANE II	Automatic Gearbox																																							
MEGANE II	A.B.S.																																							
MEGANE II	Variable P.A.S.																																							
MEGANE II	Airbag / Pretensioners																																							
MEGANE II	Airbag / Pretensioners																																							
MEGANE II	Instrument Panel		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																							
MEGANE II	Air Conditioning																																							
MEGANE II	UPC																																							
MEGANE II	UCH																																							
Nissan Pickup	Engine	Diesel																																						
Nissan Pickup	Engine	Bosch 7.9.7.1																																						
Z300	ENGINE																																							
Z300	IMMOBILIZER																																V	V	V	V	V	V	V	V
Special Function	ECU Reset																															V								

Vehicle	System	DTC Analysis	Erase	Data Analysis	Actuation Test	Identification	Special Function
A516	Engine	V	V	V	-	-	
A516	ABS	V	V	V	-	V	
A516	BCM	V	V	V	-	-	
A516	Immo	V	V	V	-	V	
A620	Engine	V	V	V	V	V	
A620	A/T	V	V	V	V	V	
A620	ABS Delphi 7.0	V	V	V	V	V	Bleeding
A620	SRS	V	V	V	-	V	
Tiggo (T11)	Engine 1.6	V	V	V	-	-	
Tiggo (T11)	Engine 2.0	V	V	V	-	-	
Tiggo (T11)	A/T	V	V	V	-	-	
Tiggo (T11)	ABS	V	V	V	V	V	Bleeding
Tiggo (T11)	IP	V	V	-	V	V	
Tiggo (T11)	SRS	V	V	-	-	V	
Tiggo (T11)	ISU	-		V	V	V	
Tiggo (T11)	Immo	V	V	V	-	V	
A113	Engine	V	V	V	V	V	
A113	ABS	V	V	V	V	V	Bleeding
M11	System Search						
M11	ENGINE	V	V	V	V	V	
M11	AT	V	V	V	V		
M11	ABS	V	V	V		V	ESC RESET ESC Special Sensor Calibration Air Bleeding ABS Air Bleeding ESC
M11	SRS	V	V				
M11	EPS	V	V	V			Tuning Table Position Sensor EOL Calibration
M11	BCM	V	V	V	V		
M11	ICM	V	V	V	V	V	ECU Reset Reset Car Maintenance Car Maintenance Function Warning LED
M11	TPMS	V	V	V		V	
M11	IMMMO	V	V			V	

Vehicle	System	DTC Analysis	Erase	Data Analysis	Actuation Test	Identification	Special Function
M12	System Search						
M12	ENGINE	V	V	V	V	V	
M12	AT	V	V	V	V		
M12	ABS	V	V	V		V	ESC RESET ESC Special Sensor Calibration Air Bleeding ABS Air Bleeding ESC
M12	SRS	V	V				
M12	EPS	V	V	V			Tuning Table Position Sensor EOL Calibration
M12	BCM	V	V	V	V		
M12	ICM	V	V	V	V	V	ECU Reset Reset Car Maintenance Car Maintenance Function Warning LED
M12	TPMS	V	V	V		V	
M12	IMMMO	V	V			V	

| Vehicle | System 1 | System 2 | DTC Analysis | Data Analysis | ECU Information Display | Actuation Test | System Identification | ECU RESET | ECU Reset | TPS VALUE CLEAR(DIESEL ONLY) | Finger Data | Key Coding | Huber EGR VIN Write | Huber EGR Initial | Huber EGR System Reset | INITIALIZE SENSOR(Only ESP) | CLEAR VARIANT CODE | AIR BLEEDING(TEVES) | Reset Adaption | Read and Write Adaption | Select Sensor Reset Item | Erase Codings | Air Bleeding(TEVES) | Key Coding Status | Leak Detection | Rail Pressure Reset | Injector Coding | Variant Coding | C3I 5 Injector Corrections | Engine Variant Coding | Chassis Variant Coding | Air Bleeding | C3I 4 Injector Corrections | TCU Adaptation Reset | TCU Initial hydraulic calibration | TCU Coding | Kyron | Actyon | Actyon Sports | Rexton | Korando C | Korando Sports | Remote Coding | EGR Position Relearning | Throttle Position Relearning | Swirl Valve Relearning | Rail Pressure Initialization | O2 Sensor Initialization | VIN Write | Coding Erase | Longitudinal acceleration sensor | Steering Reset | CDPF Regeneration | CDPF Reset | VGT Reset | Pressure Sensor Reset | Fuel Pressure Silence Test | Fuel Pressure Dynamic Test | IMV Dynamic Test | Injector Calibration | DPF Regeneration(IDLE) | DPF Regeneration(DRIVE) | LNT Desulfurization | DPF Reset | Differential Pressure Sensor Reset | LNT Reset | RPC Reset | Air Flow Sensor Reset | Cam/Crank Sensor Reset | Main Relay Reset |
|---|---|---

| Vehicle | System 1 | System 2 | DTC Analysis | Data Analysis | ECU Information Display | Actuation Test | System Identification | ECU RESET | ECU Reset | TPS VALUE CLEAR(DIESEL ONLY) | Finger Data | Key Coding | Huber EGR VIN Write | Huber EGR Initial | Huber EGR System Reset | INITIALIZE SENSOR(Only ESP) | CLEAR VARIANT CODE | AIR BLEEDING(TEVES) | Reset Adaption | Read and Write Adaption | Select Sensor Reset Item | Erase Codings | Air Bleeding(TEVES) | Key Coding Status | Leak Detection | Rail Pressure Reset | Injector Coding | Variant Coding | C3I 5 Injector Corrections | Engine Variant Coding | Chassis Variant Coding | Air Bleeding | C3I 4 Injector Corrections | TCU Adaptation Reset | TCU Initial hydraulic calibration | TCU Coding | Kyron | Actyon | Actyon Sports | Rexton | Korando C | Korando Sports | Remote Coding | EGR Position Relearning | Throttle Position Relearning | Swirl Valve Relearning | Rail Pressure Initialization | O2 Sensor Initialization | VIN Write | Coding Erase | Longitudinal acceleration sensor | Steering Reset | CDPF Regeneration | CDPF Reset | VGT Reset | Pressure Sensor Reset | Fuel Pressure Silence Test | Fuel Pressure Dynamic Test | IMV Dynamic Test | Injector Calibration | DPF Regeneration(IDLE) | DPF Regeneration(DRIVE) | LNT Desulfurization | DPF Reset | Differential Pressure Sensor Reset | LNT Reset | RPC Reset | Air Flow Sensor Reset | Cam/Crank Sensor Reset | Main Relay Reset |
|---|---|---

| Vehicle | System 1 | System 2 | DTC Analysis | Data Analysis | ECU Information Display | Actuation Test | System Identification | ECU RESET | ECU Reset | TPS VALUE CLEAR(DIESEL ONLY) | Finger Data | Key Coding | Huber EGR VIN Write | Huber EGR Initial | Huber EGR System Reset | INITIALIZE SENSOR(Only ESP) | CLEAR VARIANT CODE | AIR BLEEDING(TEVES) | Reset Adaption | Read and Write Adaption | Select Sensor Reset Item | Erase Codings | Air Bleeding(TEVES) | Key Coding Status | Leak Detection | Rail Pressure Reset | Injector Coding | Variant Coding | C3I 5 Injector Corrections | Engine Variant Coding | Chassis Variant Coding | Air Bleeding | C3I 4 Injector Corrections | TCU Adaptation Reset | TCU Initial hydraulic calibration | TCU Coding | Kyron | Actyon | Actyon Sports | Rexton | Korando C | Korando Sports | Remote Coding | EGR Position Relearning | Throttle Position Relearning | Swirl Valve Relearning | Rail Pressure Initialization | O2 Sensor Initialization | VIN Write | Coding Erase | Longitudinal acceleration sensor | Steering Reset | CDPF Regeneration | CDPF Reset | VGT Reset | Pressure Sensor Reset | Fuel Pressure Silence Test | Fuel Pressure Dynamic Test | IMV Dynamic Test | Injector Calibration | DPF Regeneration(IDLE) | DPF Regeneration(DRIVE) | LNT Desulfurization | DPF Reset | Differential Pressure Sensor Reset | LNT Reset | RPC Reset | Air Flow Sensor Reset | Cam/Crank Sensor Reset | Main Relay Reset |
|---|---|---

| Vehicle | System 1 | System 2 | DTC Analysis | Data Analysis | ECU Information Display | Actuation Test | System Identification | ECU RESET | ECU Reset | TPS VALUE CLEAR(DIESEL ONLY) | Finger Data | Key Coding | Huber EGR VIN Write | Huber EGR Initial | Huber EGR System Reset | INITIALIZE SENSOR(Only ESP) | CLEAR VARIANT CODE | AIR BLEEDING(TEVES) | Reset Adaption | Read and Write Adaption | Select Sensor Reset Item | Erase Codings | Air Bleeding(TEVES) | Key Coding Status | Leak Detection | Rail Pressure Reset | Injector Coding | Variant Coding | C3I 5 Injector Corrections | Engine Variant Coding | Chassis Variant Coding | Air Bleeding | C3I 4 Injector Corrections | TCU Adaptation Reset | TCU Initial hydraulic calibration | TCU Coding | Kyron | Actyon | Actyon Sports | Rexton | Korando C | Korando Sports | Remote Coding | EGR Position Relearning | Throttle Position Relearning | Swirl Valve Relearning | Rail Pressure Initialization | O2 Sensor Initialization | VIN Write | Coding Erase | Longitudinal acceleration sensor | Steering Reset | CDPF Regeneration | CDPF Reset | VGT Reset | Pressure Sensor Reset | Fuel Pressure Silence Test | Fuel Pressure Dynamic Test | IMV Dynamic Test | Injector Calibration | DPF Regeneration(IDLE) | DPF Regeneration(DRIVE) | LNT Desulfurization | DPF Reset | Differential Pressure Sensor Reset | LNT Reset | RPC Reset | Air Flow Sensor Reset | Cam/Crank Sensor Reset | Main Relay Reset |
|---|---|---

| Vehicle | System 1 | System 2 | DTC Analysis | Data Analysis | ECU Information Display | Actuation Test | System Identification | ECU RESET | ECU Reset | TPS VALUE CLEAR(DIESEL ONLY) | Finger Data | Key Coding | Huber EGR VIN Write | Huber EGR Initial | Huber EGR System Reset | INITIALIZE SENSOR(Only ESP) | CLEAR VARIANT CODE | AIR BLEEDING(TEVES) | Reset Adaption | Read and Write Adaption | Select Sensor Reset Item | Erase Codings | Air Bleeding(TEVES) | Key Coding Status | Leak Detection | Rail Pressure Reset | Injector Coding | Variant Coding | C3I 5 Injector Corrections | Engine Variant Coding | Chassis Variant Coding | Air Bleeding | C3I 4 Injector Corrections | TCU Adaptation Reset | TCU Initial hydraulic calibration | TCU Coding | Kyron | Actyon | Actyon Sports | Rexton | Korando C | Korando Sports | Remote Coding | EGR Position Relearning | Throttle Position Relearning | Swirl Valve Relearning | Rail Pressure Initialization | O2 Sensor Initialization | VIN Write | Coding Erase | Longitudinal acceleration sensor | Steering Reset | CDPF Regeneration | CDPF Reset | VGT Reset | Pressure Sensor Reset | Fuel Pressure Silence Test | Fuel Pressure Dynamic Test | IMV Dynamic Test | Injector Calibration | DPF Regeneration(IDLE) | DPF Regeneration(DRIVE) | LNT Desulfurization | DPF Reset | Differential Pressure Sensor Reset | LNT Reset | RPC Reset | Air Flow Sensor Reset | Cam/Crank Sensor Reset | Main Relay Reset |
|---|---|---

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(2002 - Present)	16PIN CONNECTOR				SYSTEM SEARCH																																				
International(2002 - Present)	16PIN CONNECTOR				Engine	V	V		V						V	V	V																						V	V	V
International(2002 - Present)	16PIN CONNECTOR				Immobilizer																												V	V	V	V	V	V			
International(2002 - Present)	16PIN CONNECTOR				AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(2002 - Present)	16PIN CONNECTOR				ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(2002 - Present)	16PIN CONNECTOR				EPB(Electonic parking brake)	V	V		V												V	V	V	V	V	V														
International(2002 - Present)	16PIN CONNECTOR				BVPM(Brake vacuum pump)	V	V																																	
International(2002 - Present)	16PIN CONNECTOR				PSS(Power steering system)	V	V		V																															
International(2002 - Present)	16PIN CONNECTOR				SRS Airbag	V	V		V																															
International(2002 - Present)	16PIN CONNECTOR				BCM(Body Control Module)	V	V	V	V																						V	V								
International(2002 - Present)	16PIN CONNECTOR				TPM(Tire pressure monitor)	V	V		V																															
International(2002 - Present)	16PIN CONNECTOR				ODS(Occupant detection system)	V	V		V	V		V																												
International(2002 - Present)	16PIN CONNECTOR				Meter(Combination meter)	V	V	V	V																															
International(2002 - Present)	16PIN CONNECTOR				AC(Air condition system)	V	V		V		V																													
International(2002 - Present)	16PIN CONNECTOR				ALW(Automatic light and wiper system)	V	V		V																															
International(2002 - Present)	16PIN CONNECTOR				AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(2002 - Present)	16PIN CONNECTOR				MFD(Multi function display)	V			V																															
International(2002 - Present)	16PIN CONNECTOR				Eye sight	V	V	V	V																															
International(2002 - Present)	16PIN CONNECTOR				ASS(Auto start/stop)	V	V		V																															
International(- 2002)	ALCYONE SVX	CXD	EG33 DOHC(N/A)	'91.09-'97.12	SYSTEM SEARCH																																			
International(- 2002)	ALCYONE SVX	CXD	EG33 DOHC(N/A)	'91.09-'97.12	Engine	V	V		V																															
International(- 2002)	ALCYONE SVX	CXD	EG33 DOHC(N/A)	'91.09-'97.12	AT(Auto Transmission)	V	V		V																															
International(- 2002)	ALCYONE SVX	CXD	EG33 DOHC(N/A)	'91.09-'97.12	ABS(Antilocked Braking System)	V	V		V																															
International(- 2002)	ALCYONE SVX	CXW	EG33 DOHC(N/A)	'91.09-'97.12	SYSTEM SEARCH																																			
International(- 2002)	ALCYONE SVX	CXW	EG33 DOHC(N/A)	'91.09-'97.12	Engine	V	V		V																															
International(- 2002)	ALCYONE SVX	CXW	EG33 DOHC(N/A)	'91.09-'97.12	AT(Auto Transmission)	V	V		V																															
International(- 2002)	ALCYONE SVX	CXW	EG33 DOHC(N/A)	'91.09-'97.12	ABS(Antilocked Braking System)	V	V		V																															
International(- 2002)	DEX	M401F	K3-VE	'08.11-'12.07	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	DEX	M411F	K3-VE	'08.11-'12.07	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	DIAS WAGON	S321N	KF-DET	'09.09-'14.03	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	DIAS WAGON	S321N	KF-DET	'14.04-	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	DIAS WAGON	S331N	KF-DET	'09.09-'14.03	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	DIAS WAGON	S331N	KF-DET	'14.04-	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	DOMINGO	FA7	EF12 SOHC(N/A)	'94.06-'95.10	SYSTEM SEARCH																																			
International(- 2002)	DOMINGO	FA7	EF12 SOHC(N/A)	'94.06-'95.10	Engine	V	V		V																															
International(- 2002)	DOMINGO	FA7	EF12 SOHC(N/A)	'94.06-'95.10	AT(Auto Transmission)	V	V		V																															
International(- 2002)	DOMINGO	FA7	EF12 SOHC(N/A)	'94.06-'95.10	ABS(Antilocked Braking System)	V	V		V																															
International(- 2002)	DOMINGO	FA7	EF12 SOHC(N/A)	'95.11-'96.08	SYSTEM SEARCH																																			
International(- 2002)	DOMINGO	FA7	EF12 SOHC(N/A)	'95.11-'96.08	Engine	V	V		V																															
International(- 2002)	DOMINGO	FA7	EF12 SOHC(N/A)	'95.11-'96.08	AT(Auto Transmission)	V	V		V																															
International(- 2002)	DOMINGO	FA7	EF12 SOHC(N/A)	'95.11-'96.08	ABS(Antilocked Braking System)	V	V		V																															
International(- 2002)	DOMINGO	FA7	EF12 SOHC(N/A)	'96.09-'98.12	SYSTEM SEARCH																																			
International(- 2002)	DOMINGO	FA7	EF12 SOHC(N/A)	'96.09-'98.12	Engine	V	V		V																															
International(- 2002)	DOMINGO	FA7	EF12 SOHC(N/A)	'96.09-'98.12	AT(Auto Transmission)	V	V		V																															
International(- 2002)	DOMINGO	FA7	EF12 SOHC(N/A)	'96.09-'98.12	ABS(Antilocked Braking System)	V	V		V																															

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	DOMINGO	FA8	EF12 SOHC(N/A)	'94.06-'95.10	SYSTEM SEARCH																																				
International(- 2002)	DOMINGO	FA8	EF12 SOHC(N/A)	'94.06-'95.10	Engine	V	V		V																																
International(- 2002)	DOMINGO	FA8	EF12 SOHC(N/A)	'94.06-'95.10	AT(Auto Transmission)	V	V		V																																
International(- 2002)	DOMINGO	FA8	EF12 SOHC(N/A)	'94.06-'95.10	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	DOMINGO	FA8	EF12 SOHC(N/A)	'95.11-'96.08	SYSTEM SEARCH																																				
International(- 2002)	DOMINGO	FA8	EF12 SOHC(N/A)	'95.11-'96.08	Engine	V	V		V																																
International(- 2002)	DOMINGO	FA8	EF12 SOHC(N/A)	'95.11-'96.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	DOMINGO	FA8	EF12 SOHC(N/A)	'95.11-'96.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	DOMINGO	FA8	EF12 SOHC(N/A)	'96.09-'98.12	SYSTEM SEARCH																																				
International(- 2002)	DOMINGO	FA8	EF12 SOHC(N/A)	'96.09-'98.12	Engine	V	V		V																																
International(- 2002)	DOMINGO	FA8	EF12 SOHC(N/A)	'96.09-'98.12	AT(Auto Transmission)	V	V		V																																
International(- 2002)	DOMINGO	FA8	EF12 SOHC(N/A)	'96.09-'98.12	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	DOMINGO	KJ5	EF10 SOHC(N/A)	'91.09-'92.08	SYSTEM SEARCH																																				
International(- 2002)	DOMINGO	KJ5	EF10 SOHC(N/A)	'91.09-'92.08	Engine	V	V		V																																
International(- 2002)	DOMINGO	KJ5	EF10 SOHC(N/A)	'91.09-'92.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	DOMINGO	KJ5	EF10 SOHC(N/A)	'91.09-'92.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	DOMINGO	KJ5	EF10 SOHC(N/A)	'92.09-'94.05	SYSTEM SEARCH																																				
International(- 2002)	DOMINGO	KJ5	EF10 SOHC(N/A)	'92.09-'94.05	Engine	V	V		V																																
International(- 2002)	DOMINGO	KJ5	EF10 SOHC(N/A)	'92.09-'94.05	AT(Auto Transmission)	V	V		V																																
International(- 2002)	DOMINGO	KJ5	EF10 SOHC(N/A)	'92.09-'94.05	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	DOMINGO	KJ8	EF12 SOHC(N/A)	'91.09-'92.08	SYSTEM SEARCH																																				
International(- 2002)	DOMINGO	KJ8	EF12 SOHC(N/A)	'91.09-'92.08	Engine	V	V		V																																
International(- 2002)	DOMINGO	KJ8	EF12 SOHC(N/A)	'91.09-'92.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	DOMINGO	KJ8	EF12 SOHC(N/A)	'91.09-'92.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	DOMINGO	KJ8	EF12 SOHC(N/A)	'92.09-'94.05	SYSTEM SEARCH																																				
International(- 2002)	DOMINGO	KJ8	EF12 SOHC(N/A)	'92.09-'94.05	Engine	V	V		V																																
International(- 2002)	DOMINGO	KJ8	EF12 SOHC(N/A)	'92.09-'94.05	AT(Auto Transmission)	V	V		V																																
International(- 2002)	DOMINGO	KJ8	EF12 SOHC(N/A)	'92.09-'94.05	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'08.06-'09.08	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.09-'09.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'09.12-'10.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.05-'10.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'10.08-'11.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA4	EJ20 DOHC(N/A)	'11.06-'12.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'08.06-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.09-'09.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'09.12-'10.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.05-'10.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'10.08-'11.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	AC(Air condition system)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	MFD(Multi function display)	V			V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'11.06-'12.05	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	SYSTEM SEARCH																																			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	PSS(Power steering system)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	SRS Airbag	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	AC(Air condition system)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	MFD(Multi function display)	V			V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'12.06-'13.01	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	SYSTEM SEARCH																																			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	PSS(Power steering system)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	SRS Airbag	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	AC(Air condition system)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	MFD(Multi function display)	V			V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(N/A)	'13.02-'13.06	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	SYSTEM SEARCH																																			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																			

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'08.06-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.09-'09.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'09.12-'10.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.05-'10.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'10.08-'11.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'11.06-'12.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	EPB(Electonic parking brake)	V	V		V												V	V	V	V	V	V															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'12.06-'13.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	EPB(Electonic parking brake)	V	V		V												V	V	V	V	V	V															
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.02-'13.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	Immobilizer																												V	V	V	V	V	V			

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'13.07-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.04-'14.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	ALW(Automatic light and wiper system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA5	EJ20 DOHC(T/C)	'14.07-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'09.09-'10.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.05-'10.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	SRS Airbag	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'10.08-'11.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YA9	EJ25 SOHC(N/A)	'11.06-'12.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'12.06-'13.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	Engine	V	V		V						V	V	V																						V	V	V

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.02-'13.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'13.07-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	AC(Air condition system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.04-'14.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	SYSTEM SEARCH																																				
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	PSS(Power steering system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	SRS Airbag	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	AC(Air condition system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	MFD(Multi function display)	V			V																																
International(- 2002)	EXIGA	YAM	FB25 DOHC(N/A)	'14.07-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'97.02-'98.08	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'97.02-'98.08	Engine	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'97.02-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'97.02-'98.08	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'97.02-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'97.02-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'97.02-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'97.02-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'97.02-'98.08	Immobilizer																												V								
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'98.09-'99.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.01-'00.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SF5	EJ20 DOHC(T/C)	'00.12-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'97.02-'98.08	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'97.02-'98.08	Engine	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'97.02-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'97.02-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'97.02-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'97.02-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'97.02-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'97.02-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'97.02-'98.08	Immobilizer																											V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'98.09-'99.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.01-'00.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SF5	EJ20 SOHC(N/A)	'00.12-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'98.09-'99.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.01-'00.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SF9	EJ25 DOHC(N/A)	'00.12-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'02.02-'03.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'03.02-'04.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'04.02-'04.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.01-'05.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	AC(Air condition system)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	MFD(Multi function display)	V			V																															
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'05.12-'06.12	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	SYSTEM SEARCH																																			
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	PSS(Power steering system)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	SRS Airbag	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	AC(Air condition system)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	MFD(Multi function display)	V			V																															
International(- 2002)	FORESTER	SG5	EJ20 DOHC(T/C)	'07.01-'07.11	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	SYSTEM SEARCH																																			
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	PSS(Power steering system)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	SRS Airbag	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	AC(Air condition system)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	MFD(Multi function display)	V			V																															
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'02.02-'03.01	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	SYSTEM SEARCH																																			
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	AT(Auto Transmission)	V	V		V									V	V	V	V																			

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A, Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'03.02-'04.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'04.02-'04.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.01-'05.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'05.12-'06.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SG5	EJ20 SOHC(N/A)	'07.01-'07.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'04.02-'04.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.01-'05.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'05.12-'06.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	Immobilizer																											V	V	V	V	V	V				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SG9	EJ25 DOHC(T/C)	'07.01-'07.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'07.12-'08.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	ALW(Automatic light and wiper system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(N/A)	'09.01-'10.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'07.12-'08.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'09.01-'10.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	SRS Airbag	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SH5	EJ20 DOHC(T/C)	'10.10-'12.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SH9	EJ25 DOHC(T/C)	'10.10-'12.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SHJ	FB20 DOHC(N/A)	'10.10-'12.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	Engine	V	V		V						V	V	V																						V	V	V

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'12.10-'13.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'13.10-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	AC(Air condition system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SJ5	FB20 DOHC(N/A)	'14.04-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'12.10-'13.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'13.10-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	SYSTEM SEARCH																																				
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	SRS Airbag	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	AC(Air condition system)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	MFD(Multi function display)	V			V																																
International(- 2002)	FORESTER	SJG	FA20 DOHC(T/C)	'14.04-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'92.11-'93.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'92.11-'93.09	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'92.11-'93.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'92.11-'93.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'93.10-'94.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'93.10-'94.09	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'93.10-'94.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'93.10-'94.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'94.10-'95.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'94.10-'95.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'94.10-'95.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'94.10-'95.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'95.09-'96.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'95.09-'96.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'95.09-'96.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'95.09-'96.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'96.09-'97.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'96.09-'97.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'96.09-'97.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'96.09-'97.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'97.09-'98.08	Immobilizer																											V									
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'98.09-'99.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GC1	EJ15 SOHC(N/A)	'99.09-'00.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'96.09-'97.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'96.09-'97.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'96.09-'97.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'96.09-'97.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'97.09-'98.08	Immobilizer																												V								
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'98.09-'99.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GC2	EJ15 SOHC(N/A)	'99.09-'00.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'92.11-'93.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'92.11-'93.09	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'92.11-'93.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'92.11-'93.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'93.10-'94.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'93.10-'94.09	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'93.10-'94.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'93.10-'94.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'94.10-'95.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'94.10-'95.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'94.10-'95.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'94.10-'95.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'95.09-'96.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'95.09-'96.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'95.09-'96.08	AT(Auto Transmission)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA	GC4	EJ16 SOHC(N/A)	'95.09-'96.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'92.11-'93.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'92.11-'93.09	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'92.11-'93.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'92.11-'93.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'93.10-'94.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'93.10-'94.09	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'93.10-'94.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'93.10-'94.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'94.10-'95.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'94.10-'95.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'94.10-'95.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'94.10-'95.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'95.09-'96.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'95.09-'96.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'95.09-'96.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC6	EJ18 SOHC(N/A)	'95.09-'96.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(N/A)	'98.09-'00.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'92.11-'93.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'92.11-'93.09	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'92.11-'93.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'92.11-'93.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'93.10-'94.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'93.10-'94.09	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'93.10-'94.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'93.10-'94.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'94.10-'95.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'94.10-'95.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'94.10-'95.08	AT(Auto Transmission)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'94.10-'95.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'95.09-'96.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'95.09-'96.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'95.09-'96.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'95.09-'96.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'96.09-'97.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'96.09-'97.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'96.09-'97.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'96.09-'97.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	Immobilizer																												V								
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'96.09-'97.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'96.09-'97.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'96.09-'97.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'96.09-'97.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GC8	EJ20 SOHC(N/A)	'97.09-'98.08	Immobilizer																												V								
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'03.09-'04.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	SRS Airbag	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'04.06-'05.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'05.06-'06.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GD2	EJ15 SOHC(N/A)	'06.06-'07.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	Engine	V	V		V						V	V	V																						V	V	V

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	Immobilizer																													V	V	V	V	V	V			
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'03.09-'04.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	Immobilizer																													V	V	V	V	V	V			
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'04.06-'05.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	Immobilizer																													V	V	V	V	V	V			
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	AC(Air condition system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'05.06-'06.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GD3	EJ15 SOHC(N/A)	'06.06-'07.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'00.08-'01.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'01.09-'02.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GD9	EJ20 DOHC(N/A)	'02.11-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'00.08-'01.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'01.09-'02.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'02.11-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	Meter(Combination meter)	V	V	V	V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'03.09-'04.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'04.06-'05.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'05.06-'06.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GDA	EJ20 DOHC(T/C)	'06.06-'07.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GDC	EL15 DOHC(N/A)	'06.06-'07.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA	GDD	EL15 DOHC(N/A)	'06.06-'07.06	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	PSS(Power steering system)	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	SRS Airbag	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	AC(Air condition system)	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	MFD(Multi function display)	V			V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'08.10-'09.08	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	SYSTEM SEARCH																																			
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	PSS(Power steering system)	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	SRS Airbag	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	AC(Air condition system)	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	MFD(Multi function display)	V			V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'09.09-'10.05	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	SYSTEM SEARCH																																			
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	PSS(Power steering system)	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	SRS Airbag	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	ODS(Occupant detection system)	V	V		V			V																												

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA ANESIS	GE2	EL15 DOHC(N/A)	'10.06-'11.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'08.10-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'09.09-'10.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA ANESIS	GE3	EL15 DOHC(N/A)	'10.06-'11.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'08.10-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'09.09-'10.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA ANESIS	GE6	EJ20 SOHC(N/A)	'10.06-'11.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'08.10-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'09.09-'10.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA ANESIS	GE7	EJ20 SOHC(N/A)	'10.06-'11.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC1	EJ15 SOHC(N/A)	'95.01-'96.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA COUPE	GC1	EJ15 SOHC(N/A)	'95.01-'96.12	Engine	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC1	EJ15 SOHC(N/A)	'95.01-'96.12	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC1	EJ15 SOHC(N/A)	'95.01-'96.12	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC4	EJ16 SOHC(N/A)	'95.01-'96.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA COUPE	GC4	EJ16 SOHC(N/A)	'95.01-'96.12	Engine	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC4	EJ16 SOHC(N/A)	'95.01-'96.12	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC4	EJ16 SOHC(N/A)	'95.01-'96.12	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.01-'97.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.01-'97.08	Engine	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.01-'97.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.01-'97.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.01-'97.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.01-'97.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.01-'97.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.01-'97.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.01-'97.08	Immobilizer																											V									
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	Immobilizer																												V								
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA COUPE	GC8	EJ20 DOHC(T/C)	'99.09-'00.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	BCM(Body Control Module)	V	V	V	V																					V	V										
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'11.12-'12.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	BCM(Body Control Module)	V	V	V	V																					V	V										
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'12.09-'13.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	BCM(Body Control Module)	V	V	V	V																					V	V										
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.06-'13.09	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A, Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'13.10-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ2	FB16 DOHC(N/A)	'14.04-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'11.12-'12.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'12.09-'13.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.06-'13.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'13.10-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ3	FB16 DOHC(N/A)	'14.04-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'11.12-'12.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'12.09-'13.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.06-'13.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	AC(Air condition system)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	MFD(Multi function display)	V			V																															
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'13.10-'14.03	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	SYSTEM SEARCH																																			
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	PSS(Power steering system)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	SRS Airbag	V	V		V																															
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	AC(Air condition system)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	MFD(Multi function display)	V			V																															
International(- 2002)	IMPREZA G4	GJ6	FB20 DOHC(N/A)	'14.04-	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	SYSTEM SEARCH																																			
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	PSS(Power steering system)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	SRS Airbag	V	V		V																															
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	AC(Air condition system)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	MFD(Multi function display)	V			V																															
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'11.12-'12.08	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	SYSTEM SEARCH																																			
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	AT(Auto Transmission)	V	V		V									V	V	V	V																			

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'12.09-'13.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.06-'13.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'13.10-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA G4	GJ7	FB20 DOHC(N/A)	'14.04-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'07.06-'08.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'08.10-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'09.09-'10.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH2	EL15 DOHC(N/A)	'10.06-'11.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	Immobilizer																											V	V	V	V	V	V				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'07.06-'08.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'08.10-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	ALW(Automatic light and wiper system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'09.09-'10.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH3	EL15 DOHC(N/A)	'10.06-'11.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'08.10-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	SRS Airbag	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'09.09-'10.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH6	EJ20 SOHC(N/A)	'10.06-'11.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'07.06-'08.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	Engine	V	V		V						V	V	V																						V	V	V

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'08.10-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'09.09-'10.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	AC(Air condition system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH7	EJ20 SOHC(N/A)	'10.06-'11.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'07.06-'08.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'08.10-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'09.09-'10.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK	GH8	EJ20 DOHC(T/C)	'10.06-'11.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'07.10-'09.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'09.02-'10.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'10.07-'12.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	Meter(Combination meter)	V	V	V	V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	AC(Air condition system)	V	V		V																																	
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	ALW(Automatic light and wiper system)	V	V		V																																	
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																												
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	MFD(Multi function display)	V			V																																	
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'12.06-'14.03	ASS(Auto start/stop)	V	V		V																																	
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	SYSTEM SEARCH																																					
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRB	EJ20 DOHC(T/C)	'14.04-'14.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'09.02-'10.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'10.07-'12.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'12.06-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA HATCHBACK STI	GRF	EJ25 DOHC(T/C)	'14.04-'14.08	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'11.12-'12.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'12.09-'13.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.06-'13.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'13.10-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP2	FB16 DOHC(N/A)	'14.04-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'11.12-'12.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'12.09-'13.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.06-'13.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'13.10-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP3	FB16 DOHC(N/A)	'14.04-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'11.12-'12.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'12.09-'13.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.06-'13.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'13.10-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP6	FB20 DOHC(N/A)	'14.04-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'11.12-'12.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'12.09-'13.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.06-'13.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'13.10-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS	GP7	FB20 DOHC(N/A)	'14.04-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'94.09-'95.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'94.09-'95.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'94.09-'95.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'94.09-'95.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'95.09-'96.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'95.09-'96.07	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'95.09-'96.07	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'95.09-'96.07	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'96.08-'97.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'96.08-'97.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'97.09-'98.08	Immobilizer																												V								
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'98.09-'99.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF1	EJ15 SOHC(N/A)	'99.09-'00.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'96.08-'97.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'96.08-'97.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'97.09-'98.08	Immobilizer																												V								
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'98.09-'99.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF2	EJ15 SOHC(N/A)	'99.09-'00.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF3	EJ16 SOHC(N/A)	'92.11-'93.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF3	EJ16 SOHC(N/A)	'92.11-'93.12	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF3	EJ16 SOHC(N/A)	'92.11-'93.12	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF3	EJ16 SOHC(N/A)	'92.11-'93.12	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF3	EJ16 SOHC(N/A)	'94.01-'94.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF3	EJ16 SOHC(N/A)	'94.01-'94.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF3	EJ16 SOHC(N/A)	'94.01-'94.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF3	EJ16 SOHC(N/A)	'94.01-'94.08	ABS(Antilocked Braking System)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GF3	EJ16 SOHC(N/A)	'94.09-'96.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF3	EJ16 SOHC(N/A)	'94.09-'96.07	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF3	EJ16 SOHC(N/A)	'94.09-'96.07	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF3	EJ16 SOHC(N/A)	'94.09-'96.07	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF4	EJ16 SOHC(N/A)	'92.11-'93.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF4	EJ16 SOHC(N/A)	'92.11-'93.12	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF4	EJ16 SOHC(N/A)	'92.11-'93.12	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF4	EJ16 SOHC(N/A)	'92.11-'93.12	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF4	EJ16 SOHC(N/A)	'94.01-'94.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF4	EJ16 SOHC(N/A)	'94.01-'94.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF4	EJ16 SOHC(N/A)	'94.01-'94.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF4	EJ16 SOHC(N/A)	'94.01-'94.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF4	EJ16 SOHC(N/A)	'94.09-'96.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF4	EJ16 SOHC(N/A)	'94.09-'96.07	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF4	EJ16 SOHC(N/A)	'94.09-'96.07	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF4	EJ16 SOHC(N/A)	'94.09-'96.07	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'96.08-'97.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'96.08-'97.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																					V	V										
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'97.09-'98.08	Immobilizer																											V									
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	BCM(Body Control Module)	V	V	V	V																					V	V										
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'98.09-'99.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF5	EJ18 SOHC(N/A)	'99.09-'00.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'92.11-'93.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'92.11-'93.09	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'92.11-'93.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'92.11-'93.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'93.10-'93.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'93.10-'93.12	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'93.10-'93.12	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'93.10-'93.12	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'94.01-'94.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'94.01-'94.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'94.01-'94.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'94.01-'94.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'94.09-'95.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'94.09-'95.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'94.09-'95.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'94.09-'95.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'95.09-'96.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'95.09-'96.07	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'95.09-'96.07	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'95.09-'96.07	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'96.08-'97.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'96.08-'97.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'97.09-'98.08	Immobilizer																												V								
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'98.09-'99.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF6	EJ18 SOHC(N/A)	'99.09-'00.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	BCM(Body Control Module)	V	V	V	V																					V	V										
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'98.09-'99.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	BCM(Body Control Module)	V	V	V	V																					V	V										
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(N/A)	'99.09-'00.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'93.10-'93.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'93.10-'93.12	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'93.10-'93.12	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'93.10-'93.12	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'94.01-'94.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'94.01-'94.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'94.01-'94.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'94.01-'94.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'94.09-'95.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'94.09-'95.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'94.09-'95.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'94.09-'95.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'95.09-'96.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'95.09-'96.07	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'95.09-'96.07	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'95.09-'96.07	ABS(Antilocked Braking System)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'96.08-'97.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'96.08-'97.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	Immobilizer																												V								
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 DOHC(T/C)	'99.09-'00.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'96.08-'97.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'96.08-'97.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GF8	EJ20 SOHC(N/A)	'97.09-'98.08	Immobilizer																												V								
International(- 2002)	IMPREZA SPORTS WAGON	GFA	EJ18 SOHC(N/A)	'92.11-'93.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GFA	EJ18 SOHC(N/A)	'92.11-'93.09	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GFA	EJ18 SOHC(N/A)	'92.11-'93.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GFA	EJ18 SOHC(N/A)	'92.11-'93.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GFA	EJ18 SOHC(N/A)	'93.10-'93.12	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GFA	EJ18 SOHC(N/A)	'93.10-'93.12	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GFA	EJ18 SOHC(N/A)	'93.10-'93.12	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GFA	EJ18 SOHC(N/A)	'93.10-'93.12	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GFA	EJ18 SOHC(N/A)	'94.01-'94.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GFA	EJ18 SOHC(N/A)	'94.01-'94.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GFA	EJ18 SOHC(N/A)	'94.01-'94.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GFA	EJ18 SOHC(N/A)	'94.01-'94.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'00.08-'01.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'01.09-'02.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'02.11-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	Meter(Combination meter)	V	V	V	V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	AC(Air condition system)	V	V		V																																	
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	ALW(Automatic light and wiper system)	V	V		V																																	
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																												
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	MFD(Multi function display)	V			V																																	
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'03.09-'04.05	ASS(Auto start/stop)	V	V		V																																	
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	SYSTEM SEARCH																																					
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																												
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	MFD(Multi function display)	V			V																																	
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'04.06-'05.05	ASS(Auto start/stop)	V	V		V																																	
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	SYSTEM SEARCH																																					
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																												
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'05.06-'06.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG2	EJ15 SOHC(N/A)	'06.06-'07.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'00.08-'01.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'01.09-'02.10	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'02.11-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'03.09-'04.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	Meter(Combination meter)	V	V	V	V																																	
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	AC(Air condition system)	V	V		V																																	
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	ALW(Automatic light and wiper system)	V	V		V																																	
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																												
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	MFD(Multi function display)	V			V																																	
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'04.06-'05.05	ASS(Auto start/stop)	V	V		V																																	
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	SYSTEM SEARCH																																					
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																												
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'05.06-'06.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																												
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG3	EJ15 SOHC(N/A)	'06.06-'07.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'00.08-'01.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'01.09-'02.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'02.11-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GG9	EJ20 DOHC(N/A)	'03.09-'04.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'00.08-'01.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'01.09-'02.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'02.11-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'03.09-'04.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'04.06-'05.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'05.06-'06.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGA	EJ20 DOHC(T/C)	'06.06-'07.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGC	EL15 DOHC(N/A)	'06.06-'07.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON	GGD	EL15 DOHC(N/A)	'06.06-'07.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'94.01-'95.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'94.01-'95.07	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'94.01-'95.07	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'94.01-'95.07	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'95.08-'96.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'95.08-'96.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'95.08-'96.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'95.08-'96.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'96.09-'97.08	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'96.09-'97.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'96.09-'97.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'96.09-'97.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'97.09-'98.08	Immobilizer																												V								
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'98.09-'99.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA SPORTS WAGON STI	GF8	EJ20 DOHC(T/C)	'99.09-'00.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'00.10-'01.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA SPORTS WAGON STI	GGB	EJ20 DOHC(T/C)	'01.09-'02.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'94.01-'95.07	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'94.01-'95.07	Engine	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'94.01-'95.07	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'94.01-'95.07	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'95.08-'96.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'95.08-'96.08	Engine	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'95.08-'96.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'95.08-'96.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'96.09-'97.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'96.09-'97.08	Engine	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'96.09-'97.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'96.09-'97.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	Engine	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'97.09-'98.08	Immobilizer																												V								
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'98.09-'99.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GC8	EJ20 DOHC(T/C)	'99.09-'00.09	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'00.10-'01.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.09-'01.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'01.12-'02.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'02.11-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'03.09-'04.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'04.06-'05.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'05.06-'06.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA STI	GDB	EJ20 DOHC(T/C)	'06.06-'07.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	PSS(Power steering system)	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	SRS Airbag	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	AC(Air condition system)	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	MFD(Multi function display)	V			V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'10.07-'12.05	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	SYSTEM SEARCH																																			
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	PSS(Power steering system)	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	SRS Airbag	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	AC(Air condition system)	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	MFD(Multi function display)	V			V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'12.06-'13.05	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	SYSTEM SEARCH																																			
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	PSS(Power steering system)	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	SRS Airbag	V	V		V																															
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	TPM(Tire pressure monitor)	V	V		V																															

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'13.06-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GVB	EJ20 DOHC(T/C)	'14.04-'14.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'10.07-'12.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'12.06-'13.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'13.06-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA STI	GVF	EJ25 DOHC(T/C)	'14.04-'14.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA XV	GH2	EL15 DOHC(N/A)	'10.06-'11.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA XV	GH3	EL15 DOHC(N/A)	'10.06-'11.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA XV	GH6	EJ20 SOHC(N/A)	'10.06-'11.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	SYSTEM SEARCH																																				
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	PSS(Power steering system)	V	V		V																																
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	SRS Airbag	V	V		V																																
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	AC(Air condition system)	V	V		V																																
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	MFD(Multi function display)	V			V																																
International(- 2002)	IMPREZA XV	GH7	EJ20 SOHC(N/A)	'10.06-'11.11	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'88.11-'90.09	SYSTEM SEARCH																																				
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'88.11-'90.09	Engine	V	V		V																																
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'88.11-'90.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'88.11-'90.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'90.10-'91.05	SYSTEM SEARCH																																				
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'90.10-'91.05	Engine	V	V		V																																
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'90.10-'91.05	AT(Auto Transmission)	V	V		V																																
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'90.10-'91.05	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'91.06-'92.08	SYSTEM SEARCH																																				
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'91.06-'92.08	Engine	V	V		V																																
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'91.06-'92.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'91.06-'92.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'92.09-'94.12	SYSTEM SEARCH																																				
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'92.09-'94.12	Engine	V	V		V																																
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'92.09-'94.12	AT(Auto Transmission)	V	V		V																																
International(- 2002)	JUSTY	KA7	EF12 SOHC(N/A)	'92.09-'94.12	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'88.11-'90.09	SYSTEM SEARCH																																				
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'88.11-'90.09	Engine	V	V		V																																
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'88.11-'90.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'88.11-'90.09	ABS(Antilocked Braking System)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'90.10-'91.05	SYSTEM SEARCH																																				
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'90.10-'91.05	Engine	V	V		V																																
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'90.10-'91.05	AT(Auto Transmission)	V	V		V																																
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'90.10-'91.05	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'91.06-'92.08	SYSTEM SEARCH																																				
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'91.06-'92.08	Engine	V	V		V																																
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'91.06-'92.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'91.06-'92.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'92.09-'94.12	SYSTEM SEARCH																																				
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'92.09-'94.12	Engine	V	V		V																																
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'92.09-'94.12	AT(Auto Transmission)	V	V		V																																
International(- 2002)	JUSTY	KA8	EF12 SOHC(N/A)	'92.09-'94.12	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'98.12-'99.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'99.05-'00.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'00.05-'01.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(N/A)	'01.05-'03.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'98.12-'99.04	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	SYSTEM SEARCH																																			
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'99.05-'00.04	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	SYSTEM SEARCH																																			
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'00.05-'01.04	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	SYSTEM SEARCH																																			
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	AT(Auto Transmission)	V	V		V									V	V	V	V																			

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BE5	EJ20 DOHC(T/C)	'01.05-'03.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BE5	EJ20 SOHC(N/A)	'01.05-'03.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BE9	EJ25 DOHC(N/A)	'01.05-'03.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BEE	EZ30 DOHC(N/A)	'01.05-'03.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BES	EJ20 DOHC(T/C)	'01.05-'03.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.06-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'03.09-'04.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'04.05-'05.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	Immobilizer																											V	V	V	V	V	V				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'05.05-'06.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'06.05-'07.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	ALW(Automatic light and wiper system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(N/A)	'07.05-'08.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.06-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'03.09-'04.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	SRS Airbag	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'04.05-'05.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'05.05-'06.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'06.05-'07.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	Engine	V	V		V						V	V	V																						V	V	V

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'07.05-'08.04	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	SYSTEM SEARCH																																			
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY B4	BL5	EJ20 DOHC(T/C)	'08.05-'09.04	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	SYSTEM SEARCH																																			
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	AC(Air condition system)	V	V		V																															

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.06-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'03.09-'04.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'04.05-'05.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'05.05-'06.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'06.05-'07.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'07.05-'08.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL5	EJ20 SOHC(N/A)	'08.05-'09.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'07.05-'08.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	Meter(Combination meter)	V	V	V	V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BL9	EJ25 SOHC(N/A)	'08.05-'09.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'03.06-'04.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'04.05-'05.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'05.05-'06.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'06.05-'07.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'07.05-'08.04	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BLE	EZ30 DOHC(N/A)	'08.05-'09.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'09.05-'10.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'10.05-'11.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'11.06-'12.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BM9	EJ25 DOHC(T/C)	'12.04-'13.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	ABS(Antilocked Braking System)	V	V		V																		V	V	V												

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	BCM(Body Control Module)	V	V	V	V																					V	V										
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'09.05-'10.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	BCM(Body Control Module)	V	V	V	V																					V	V										
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'10.05-'11.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	BCM(Body Control Module)	V	V	V	V																					V	V										
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BM9	EJ25 SOHC(N/A)	'11.06-'12.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'12.04-'13.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'13.05-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	SYSTEM SEARCH																																				
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY B4	BMG	FA20 DOHC(T/C)	'14.04-'14.09	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	SYSTEM SEARCH																																			
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'12.04-'13.04	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	SYSTEM SEARCH																																			
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'13.05-'14.03	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	SYSTEM SEARCH																																			
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	AT(Auto Transmission)	V	V		V									V	V	V	V																			

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY B4	BMM	FB25 DOHC(N/A)	'14.04-'14.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY GRAND WAGON	BG9	EJ25 DOHC(N/A)	'95.08-'96.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY GRAND WAGON	BG9	EJ25 DOHC(N/A)	'95.08-'96.05	Engine	V	V		V																																
International(- 2002)	LEGACY GRAND WAGON	BG9	EJ25 DOHC(N/A)	'95.08-'96.05	AT(Auto Transmission)	V	V		V																																
International(- 2002)	LEGACY GRAND WAGON	BG9	EJ25 DOHC(N/A)	'95.08-'96.05	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	LEGACY GRAND WAGON	BG9	EJ25 DOHC(N/A)	'96.06-'97.07	SYSTEM SEARCH																																				
International(- 2002)	LEGACY GRAND WAGON	BG9	EJ25 DOHC(N/A)	'96.06-'97.07	Engine	V	V		V																																
International(- 2002)	LEGACY GRAND WAGON	BG9	EJ25 DOHC(N/A)	'96.06-'97.07	AT(Auto Transmission)	V	V		V																																
International(- 2002)	LEGACY GRAND WAGON	BG9	EJ25 DOHC(N/A)	'96.06-'97.07	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BG9	EJ25 DOHC(N/A)	'97.08-'98.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY LANCASTER	BG9	EJ25 DOHC(N/A)	'97.08-'98.05	Engine	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BG9	EJ25 DOHC(N/A)	'97.08-'98.05	AT(Auto Transmission)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BG9	EJ25 DOHC(N/A)	'97.08-'98.05	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	Immobilizer																												V	V	V	V	V	V			

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	SYSTEM SEARCH																																				
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	ALW(Automatic light and wiper system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A, Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY LANCASTER	BH9	EJ25 DOHC(N/A)	'01.05-'03.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	BCM(Body Control Module)	V	V	V	V																					V	V										
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'00.05-'01.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	SYSTEM SEARCH																																				
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	BCM(Body Control Module)	V	V	V	V																					V	V										
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY LANCASTER	BHE	EZ30 DOHC(N/A)	'01.05-'03.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	SRS Airbag	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'03.10-'04.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'04.05-'05.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'05.05-'06.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	Engine	V	V		V						V	V	V																						V	V	V

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'06.05-'07.04	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	SYSTEM SEARCH																																			
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	SYSTEM SEARCH																																			
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	AC(Air condition system)	V	V		V																															

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'03.10-'04.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BPH	EJ25 DOHC(T/C)	'08.05-'09.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	Meter(Combination meter)	V	V	V	V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BR9	EJ25 SOHC(N/A)	'11.06-'12.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'09.05-'10.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'10.05-'11.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'11.06-'12.03	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'12.04-'13.04	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	SYSTEM SEARCH																																			
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'13.05-'14.03	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	SYSTEM SEARCH																																			
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	ODS(Occupant detection system)	V	V		V			V																												

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BRF	EZ36 DOHC(N/A)	'14.04-'14.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'12.04-'13.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'13.05-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	SYSTEM SEARCH																																				
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V															
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	PSS(Power steering system)	V	V		V																																	
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	SRS Airbag	V	V		V																																	
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	BCM(Body Control Module)	V	V	V	V																						V	V										
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	TPM(Tire pressure monitor)	V	V		V																																	
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	ODS(Occupant detection system)	V	V		V			V																														
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	Meter(Combination meter)	V	V	V	V																																	
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	AC(Air condition system)	V	V		V																																	
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	ALW(Automatic light and wiper system)	V	V		V																																	
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																												
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	MFD(Multi function display)	V			V																																	
International(- 2002)	LEGACY OUTBACK	BRM	FB25 DOHC(N/A)	'14.04-'14.09	ASS(Auto start/stop)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'89.02-'90.04	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'89.02-'90.04	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'89.02-'90.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'89.02-'90.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'90.05-'91.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'90.05-'91.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'90.05-'91.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'90.05-'91.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'91.06-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'91.06-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'91.06-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'91.06-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC2	EJ18 SOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'89.02-'90.04	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'89.02-'90.04	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'89.02-'90.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'89.02-'90.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'90.05-'91.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'90.05-'91.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'90.05-'91.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'90.05-'91.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'91.06-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'91.06-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'91.06-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'91.06-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC3	EJ18 SOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'89.02-'90.04	SYSTEM SEARCH																																					

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'89.02-'90.04	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'89.02-'90.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'89.02-'90.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'90.05-'91.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'90.05-'91.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'90.05-'91.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'90.05-'91.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'91.06-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'91.06-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'91.06-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'91.06-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 DOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 SOHC(N/A)	'91.06-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC4	EJ20 SOHC(N/A)	'91.06-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 SOHC(N/A)	'91.06-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 SOHC(N/A)	'91.06-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 SOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC4	EJ20 SOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 SOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC4	EJ20 SOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'89.02-'90.04	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'89.02-'90.04	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'89.02-'90.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'89.02-'90.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'90.05-'91.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'90.05-'91.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'90.05-'91.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'90.05-'91.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'91.06-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'91.06-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'91.06-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'91.06-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'89.02-'90.04	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'89.02-'90.04	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'89.02-'90.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'89.02-'90.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'90.05-'91.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'90.05-'91.05	Engine	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'90.05-'91.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'90.05-'91.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'91.06-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'91.06-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'91.06-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'91.06-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 DOHC(T/C)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 SOHC(N/A)	'91.06-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC5	EJ20 SOHC(N/A)	'91.06-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 SOHC(N/A)	'91.06-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 SOHC(N/A)	'91.06-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 SOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BC5	EJ20 SOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 SOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BC5	EJ20 SOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BCA	EJ20 DOHC(N/A)	'90.05-'91.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BCA	EJ20 DOHC(N/A)	'90.05-'91.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BCA	EJ20 DOHC(N/A)	'90.05-'91.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BCA	EJ20 DOHC(N/A)	'90.05-'91.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BCA	EJ20 DOHC(N/A)	'91.06-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BCA	EJ20 DOHC(N/A)	'91.06-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BCA	EJ20 DOHC(N/A)	'91.06-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BCA	EJ20 DOHC(N/A)	'91.06-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BCA	EJ20 DOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BCA	EJ20 DOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BCA	EJ20 DOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BCA	EJ20 DOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD2	EJ18 SOHC(N/A)	'93.10-'96.07	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD2	EJ18 SOHC(N/A)	'93.10-'96.07	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD2	EJ18 SOHC(N/A)	'93.10-'96.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD2	EJ18 SOHC(N/A)	'93.10-'96.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD2	EJ18 SOHC(N/A)	'96.08-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD2	EJ18 SOHC(N/A)	'96.08-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD2	EJ18 SOHC(N/A)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD2	EJ18 SOHC(N/A)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD2	EJ18 SOHC(N/A)	'97.09-'98.11	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD2	EJ18 SOHC(N/A)	'97.09-'98.11	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD2	EJ18 SOHC(N/A)	'97.09-'98.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD2	EJ18 SOHC(N/A)	'97.09-'98.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD3	EJ18 SOHC(N/A)	'93.10-'96.07	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD3	EJ18 SOHC(N/A)	'93.10-'96.07	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD3	EJ18 SOHC(N/A)	'93.10-'96.07	AT(Auto Transmission)	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY SEDAN	BD3	EJ18 SOHC(N/A)	'93.10-'96.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD3	EJ18 SOHC(N/A)	'96.08-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD3	EJ18 SOHC(N/A)	'96.08-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD3	EJ18 SOHC(N/A)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD3	EJ18 SOHC(N/A)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD3	EJ18 SOHC(N/A)	'97.09-'98.11	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD3	EJ18 SOHC(N/A)	'97.09-'98.11	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD3	EJ18 SOHC(N/A)	'97.09-'98.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD3	EJ18 SOHC(N/A)	'97.09-'98.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD4	EJ20 DOHC(N/A)	'93.10-'96.07	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD4	EJ20 DOHC(N/A)	'93.10-'96.07	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD4	EJ20 DOHC(N/A)	'93.10-'96.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD4	EJ20 DOHC(N/A)	'93.10-'96.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD4	EJ20 SOHC(N/A)	'93.10-'96.07	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD4	EJ20 SOHC(N/A)	'93.10-'96.07	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD4	EJ20 SOHC(N/A)	'93.10-'96.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD4	EJ20 SOHC(N/A)	'93.10-'96.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD4	EJ20 SOHC(N/A)	'96.08-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD4	EJ20 SOHC(N/A)	'96.08-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD4	EJ20 SOHC(N/A)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD4	EJ20 SOHC(N/A)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD4	EJ20 SOHC(N/A)	'97.09-'98.11	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD4	EJ20 SOHC(N/A)	'97.09-'98.11	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD4	EJ20 SOHC(N/A)	'97.09-'98.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD4	EJ20 SOHC(N/A)	'97.09-'98.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(N/A)	'93.10-'96.07	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(N/A)	'93.10-'96.07	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(N/A)	'93.10-'96.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(N/A)	'93.10-'96.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(N/A)	'96.08-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(N/A)	'96.08-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(N/A)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(N/A)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(N/A)	'97.09-'98.11	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(N/A)	'97.09-'98.11	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(N/A)	'97.09-'98.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(N/A)	'97.09-'98.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(T/C)	'93.10-'96.07	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(T/C)	'93.10-'96.07	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(T/C)	'93.10-'96.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(T/C)	'93.10-'96.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(T/C)	'96.08-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(T/C)	'96.08-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(T/C)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(T/C)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(T/C)	'97.09-'98.11	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(T/C)	'97.09-'98.11	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(T/C)	'97.09-'98.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 DOHC(T/C)	'97.09-'98.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 SOHC(N/A)	'93.10-'96.07	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD5	EJ20 SOHC(N/A)	'93.10-'96.07	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 SOHC(N/A)	'93.10-'96.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 SOHC(N/A)	'93.10-'96.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 SOHC(N/A)	'96.08-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD5	EJ20 SOHC(N/A)	'96.08-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 SOHC(N/A)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 SOHC(N/A)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 SOHC(N/A)	'97.09-'98.11	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD5	EJ20 SOHC(N/A)	'97.09-'98.11	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 SOHC(N/A)	'97.09-'98.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD5	EJ20 SOHC(N/A)	'97.09-'98.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD9	EJ25 DOHC(N/A)	'93.10-'96.07	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD9	EJ25 DOHC(N/A)	'93.10-'96.07	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD9	EJ25 DOHC(N/A)	'93.10-'96.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD9	EJ25 DOHC(N/A)	'93.10-'96.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD9	EJ25 DOHC(N/A)	'96.08-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD9	EJ25 DOHC(N/A)	'96.08-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD9	EJ25 DOHC(N/A)	'96.08-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD9	EJ25 DOHC(N/A)	'96.08-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD9	EJ25 DOHC(N/A)	'97.09-'98.11	SYSTEM SEARCH																																					
International(- 2002)	LEGACY SEDAN	BD9	EJ25 DOHC(N/A)	'97.09-'98.11	Engine	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD9	EJ25 DOHC(N/A)	'97.09-'98.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY SEDAN	BD9	EJ25 DOHC(N/A)	'97.09-'98.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'89.02-'90.04	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'89.02-'90.04	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'89.02-'90.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'89.02-'90.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'90.05-'91.04	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'90.05-'91.04	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'90.05-'91.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'90.05-'91.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'91.05-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'91.05-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'91.05-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'91.05-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF3	EJ18 SOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'89.02-'90.04	SYSTEM SEARCH																																					

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'89.02-'90.04	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'89.02-'90.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'89.02-'90.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'90.05-'91.04	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'90.05-'91.04	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'90.05-'91.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'90.05-'91.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'91.05-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'91.05-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'91.05-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'91.05-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'89.02-'90.04	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'89.02-'90.04	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'89.02-'90.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'89.02-'90.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'90.05-'91.04	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'90.05-'91.04	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'90.05-'91.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'90.05-'91.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'91.05-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'91.05-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'91.05-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'91.05-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 DOHC(T/C)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 SOHC(N/A)	'91.05-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 SOHC(N/A)	'91.05-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 SOHC(N/A)	'91.05-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 SOHC(N/A)	'91.05-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 SOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 SOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 SOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF5	EJ20 SOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF7	EJ22 SOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BF7	EJ22 SOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF7	EJ22 SOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BF7	EJ22 SOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'89.02-'90.04	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'89.02-'90.04	Engine	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'89.02-'90.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'89.02-'90.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'90.05-'91.04	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'90.05-'91.04	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'90.05-'91.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'90.05-'91.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'91.05-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'91.05-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'91.05-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'91.05-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 DOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 SOHC(N/A)	'91.05-'92.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 SOHC(N/A)	'91.05-'92.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 SOHC(N/A)	'91.05-'92.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 SOHC(N/A)	'91.05-'92.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 SOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 SOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 SOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFA	EJ20 SOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFB	EJ22 SOHC(N/A)	'92.06-'93.09	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BFB	EJ22 SOHC(N/A)	'92.06-'93.09	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFB	EJ22 SOHC(N/A)	'92.06-'93.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BFB	EJ22 SOHC(N/A)	'92.06-'93.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG2	EJ18 SOHC(N/A)	'96.06-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG2	EJ18 SOHC(N/A)	'96.06-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG2	EJ18 SOHC(N/A)	'96.06-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG2	EJ18 SOHC(N/A)	'96.06-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG2	EJ18 SOHC(N/A)	'97.09-'98.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG2	EJ18 SOHC(N/A)	'97.09-'98.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG2	EJ18 SOHC(N/A)	'97.09-'98.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG2	EJ18 SOHC(N/A)	'97.09-'98.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG3	EJ18 SOHC(N/A)	'93.10-'96.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG3	EJ18 SOHC(N/A)	'93.10-'96.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG3	EJ18 SOHC(N/A)	'93.10-'96.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG3	EJ18 SOHC(N/A)	'93.10-'96.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG3	EJ18 SOHC(N/A)	'96.06-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG3	EJ18 SOHC(N/A)	'96.06-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG3	EJ18 SOHC(N/A)	'96.06-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG3	EJ18 SOHC(N/A)	'96.06-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG3	EJ18 SOHC(N/A)	'97.09-'98.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG3	EJ18 SOHC(N/A)	'97.09-'98.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG3	EJ18 SOHC(N/A)	'97.09-'98.05	AT(Auto Transmission)	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BG3	EJ18 SOHC(N/A)	'97.09-'98.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG4	EJ20 SOHC(N/A)	'93.10-'96.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG4	EJ20 SOHC(N/A)	'93.10-'96.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG4	EJ20 SOHC(N/A)	'93.10-'96.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG4	EJ20 SOHC(N/A)	'93.10-'96.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG4	EJ20 SOHC(N/A)	'96.06-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG4	EJ20 SOHC(N/A)	'96.06-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG4	EJ20 SOHC(N/A)	'96.06-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG4	EJ20 SOHC(N/A)	'96.06-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG4	EJ20 SOHC(N/A)	'97.09-'98.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG4	EJ20 SOHC(N/A)	'97.09-'98.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG4	EJ20 SOHC(N/A)	'97.09-'98.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG4	EJ20 SOHC(N/A)	'97.09-'98.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(N/A)	'93.10-'96.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(N/A)	'93.10-'96.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(N/A)	'93.10-'96.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(N/A)	'93.10-'96.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(N/A)	'96.06-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(N/A)	'96.06-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(N/A)	'96.06-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(N/A)	'96.06-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(N/A)	'97.09-'98.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(N/A)	'97.09-'98.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(N/A)	'97.09-'98.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(N/A)	'97.09-'98.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(T/C)	'93.10-'96.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(T/C)	'93.10-'96.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(T/C)	'93.10-'96.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(T/C)	'93.10-'96.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(T/C)	'96.06-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(T/C)	'96.06-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(T/C)	'96.06-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(T/C)	'96.06-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(T/C)	'97.09-'98.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(T/C)	'97.09-'98.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(T/C)	'97.09-'98.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 DOHC(T/C)	'97.09-'98.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 SOHC(N/A)	'93.10-'96.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 SOHC(N/A)	'93.10-'96.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 SOHC(N/A)	'93.10-'96.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 SOHC(N/A)	'93.10-'96.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 SOHC(N/A)	'96.06-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 SOHC(N/A)	'96.06-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 SOHC(N/A)	'96.06-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 SOHC(N/A)	'96.06-'97.08	ABS(Antilocked Braking System)	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 SOHC(N/A)	'97.09-'98.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 SOHC(N/A)	'97.09-'98.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 SOHC(N/A)	'97.09-'98.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG5	EJ20 SOHC(N/A)	'97.09-'98.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG7	EJ22 SOHC(N/A)	'93.10-'96.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG7	EJ22 SOHC(N/A)	'93.10-'96.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG7	EJ22 SOHC(N/A)	'93.10-'96.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG7	EJ22 SOHC(N/A)	'93.10-'96.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG9	EJ25 DOHC(N/A)	'93.10-'96.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG9	EJ25 DOHC(N/A)	'93.10-'96.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG9	EJ25 DOHC(N/A)	'93.10-'96.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG9	EJ25 DOHC(N/A)	'93.10-'96.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG9	EJ25 DOHC(N/A)	'96.06-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG9	EJ25 DOHC(N/A)	'96.06-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG9	EJ25 DOHC(N/A)	'96.06-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG9	EJ25 DOHC(N/A)	'96.06-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG9	EJ25 DOHC(N/A)	'97.09-'98.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BG9	EJ25 DOHC(N/A)	'97.09-'98.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG9	EJ25 DOHC(N/A)	'97.09-'98.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BG9	EJ25 DOHC(N/A)	'97.09-'98.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGA	EJ20 SOHC(N/A)	'93.10-'96.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BGA	EJ20 SOHC(N/A)	'93.10-'96.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGA	EJ20 SOHC(N/A)	'93.10-'96.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGA	EJ20 SOHC(N/A)	'93.10-'96.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGA	EJ20 SOHC(N/A)	'96.06-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BGA	EJ20 SOHC(N/A)	'96.06-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGA	EJ20 SOHC(N/A)	'96.06-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGA	EJ20 SOHC(N/A)	'96.06-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGA	EJ20 SOHC(N/A)	'97.09-'98.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BGA	EJ20 SOHC(N/A)	'97.09-'98.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGA	EJ20 SOHC(N/A)	'97.09-'98.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGA	EJ20 SOHC(N/A)	'97.09-'98.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGB	EJ22 SOHC(N/A)	'93.10-'96.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BGB	EJ22 SOHC(N/A)	'93.10-'96.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGB	EJ22 SOHC(N/A)	'93.10-'96.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGB	EJ22 SOHC(N/A)	'93.10-'96.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGC	EJ25 DOHC(N/A)	'93.10-'96.05	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BGC	EJ25 DOHC(N/A)	'93.10-'96.05	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGC	EJ25 DOHC(N/A)	'93.10-'96.05	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGC	EJ25 DOHC(N/A)	'93.10-'96.05	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGC	EJ25 DOHC(N/A)	'96.06-'97.08	SYSTEM SEARCH																																					
International(- 2002)	LEGACY TOURING WAGON	BGC	EJ25 DOHC(N/A)	'96.06-'97.08	Engine	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGC	EJ25 DOHC(N/A)	'96.06-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGC	EJ25 DOHC(N/A)	'96.06-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	LEGACY TOURING WAGON	BGC	EJ25 DOHC(N/A)	'97.09-'98.05	SYSTEM SEARCH																																					

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BGC	EJ25 DOHC(N/A)	'97.09-'98.05	Engine	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BGC	EJ25 DOHC(N/A)	'97.09-'98.05	AT(Auto Transmission)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BGC	EJ25 DOHC(N/A)	'97.09-'98.05	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'98.06-'99.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'99.05-'00.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	SRS Airbag	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'00.05-'01.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(N/A)	'01.05-'03.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'98.06-'99.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	Engine	V	V		V						V	V	V																						V	V	V

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'99.05-'00.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'00.05-'01.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	AC(Air condition system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 DOHC(T/C)	'01.05-'03.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'98.06-'99.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'00.05-'01.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH5	EJ20 SOHC(N/A)	'01.05-'03.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'98.06-'99.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'99.05-'00.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'00.05-'01.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BH9	EJ25 DOHC(N/A)	'01.05-'03.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	Meter(Combination meter)	V	V	V	V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'98.06-'99.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'99.05-'00.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BHC	EJ25 DOHC(N/A)	'00.05-'01.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BHE	EZ30 DOHC(N/A)	'01.05-'03.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.05-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'03.09-'04.04	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'04.05-'05.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'05.05-'06.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'06.05-'07.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(N/A)	'07.05-'08.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.05-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'03.09-'04.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'04.05-'05.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'05.05-'06.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'06.05-'07.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'07.05-'08.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 DOHC(T/C)	'08.05-'09.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.05-'03.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'03.09-'04.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'04.05-'05.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'05.05-'06.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'06.05-'07.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'07.05-'08.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BP5	EJ20 SOHC(N/A)	'08.05-'09.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'07.05-'08.04	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	SYSTEM SEARCH																																			
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY TOURING WAGON	BP9	EJ25 SOHC(N/A)	'08.05-'09.04	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	SYSTEM SEARCH																																			
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'03.05-'04.04	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	SYSTEM SEARCH																																			
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	Immobilizer																											V	V	V	V	V	V			

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'04.05-'05.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'05.05-'06.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	ALW(Automatic light and wiper system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'06.05-'07.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'07.05-'08.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BPE	EZ30 DOHC(N/A)	'08.05-'09.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	SRS Airbag	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'09.05-'10.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'10.05-'11.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'11.06-'12.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	Engine	V	V		V						V	V	V																						V	V	V

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 DOHC(T/C)	'12.04-'13.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'09.05-'10.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	AC(Air condition system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'10.05-'11.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BR9	EJ25 SOHC(N/A)	'11.06-'12.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'12.04-'13.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'13.05-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BRG	FA20 DOHC(T/C)	'14.04-'14.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	SYSTEM SEARCH																																				
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	SRS Airbag	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	AC(Air condition system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	MFD(Multi function display)	V			V																																
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'12.04-'13.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'13.05-'14.03	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	SYSTEM SEARCH																																			
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	PSS(Power steering system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	SRS Airbag	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	AC(Air condition system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	MFD(Multi function display)	V			V																															
International(- 2002)	LEGACY TOURING WAGON	BRM	FB25 DOHC(N/A)	'14.04-'14.10	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	LEONE VAN	VENY11	YD22DD	'99.06-'03.03	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	LEONE VAN	VFNY10	GA15DE	'95.06-'98.03	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	LEONE VAN	VFNY10	GA15DE	'98.04-'99.05	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	LEONE VAN	VFY10	GA15DE	'95.06-'98.03	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	LEONE VAN	VFY10	GA15DE	'98.04-'99.05	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	LEONE VAN	VFY11	QG15DE	'99.05-'00.01	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	LEONE VAN	VFY11	QG15DE	'00.01-'02.08	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	LEONE VAN	VFY11	QG15DE	'02.08-'03.03	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	LEONE VAN	VHNY11	QG18DE	'99.05-'00.01	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	LEONE VAN	VHNY11	QG18DE	'00.01-'02.08	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	LEONE VAN	VHNY11	QG18DE	'02.08-'03.03	Please select the original manufacturer of the vehicle.																																			
International(- 2002)	LEONE VAN	VY10	GA13DE	'97.05-'98.03	Please select the original manufacturer of the vehicle.																																			

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LEONE VAN	VY10	GA13DE	'98.04-'99.05	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LEONE VAN	VY11	QG13DE	'99.05-'00.01	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LEONE VAN	VY11	QG13DE	'00.01-'02.08	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LEONE VAN	VY11	QG13DE	'02.08-'03.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	SYSTEM SEARCH																																				
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	SRS Airbag	V	V		V																																
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	AC(Air condition system)	V	V		V																																
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	MFD(Multi function display)	V			V																																
International(- 2002)	LEVORG	VM4	FB16 DOHC(T/C)	'14.06-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	SYSTEM SEARCH																																				
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	PSS(Power steering system)	V	V		V																																
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	SRS Airbag	V	V		V																																
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	AC(Air condition system)	V	V		V																																
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	MFD(Multi function display)	V			V																																
International(- 2002)	LEVORG	VMG	FA20 DOHC(T/C)	'14.06-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	LUCRA	L455F	KF-DET	'10.04-'10.09	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L455F	KF-DET	'10.10-'11.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L455F	KF-DET	'11.07-'11.12	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L455F	KF-DET	'12.01-'12.08	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L455F	KF-DET	'12.09-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L455F	KF-DET	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L455F	KF-VE	'10.04-'10.09	Please select the original manufacturer of the vehicle.																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	LUCRA	L455F	KF-VE	'10.10-'11.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L455F	KF-VE	'11.07-'11.12	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L455F	KF-VE	'12.01-'12.08	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L455F	KF-VE	'12.09-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L455F	KF-VE	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L465F	KF-DET	'10.04-'10.09	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L465F	KF-DET	'10.10-'11.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L465F	KF-DET	'11.07-'11.12	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L465F	KF-DET	'12.01-'12.08	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L465F	KF-DET	'12.09-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L465F	KF-DET	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L465F	KF-VE	'10.04-'10.09	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L465F	KF-VE	'10.10-'11.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L465F	KF-VE	'11.07-'11.12	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L465F	KF-VE	'12.01-'12.08	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L465F	KF-VE	'12.09-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	LUCRA	L465F	KF-VE	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L275B	KF-VE	'10.04-'11.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L275B	KF-VE	'11.07-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L275B	KF-VE	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L275F	KF-DET	'10.04-'11.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L275F	KF-VE	'10.04-'11.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L275F	KF-VE	'11.07-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L275F	KF-VE	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L285B	KF-VE	'10.04-'11.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L285B	KF-VE	'11.07-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L285B	KF-VE	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L285F	KF-DET	'10.04-'11.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L285F	KF-VE	'10.04-'11.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L285F	KF-VE	'11.07-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	L285F	KF-VE	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	LA300F	KF-VE	'12.12-'13.07	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	LA300F	KF-VE	'13.08-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	LA300F	KF-VE	'14.04-'14.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	LA300F	KF-VE	'14.07-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	LA310F	KF-VE	'12.12-'13.07	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	LA310F	KF-VE	'13.08-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	LA310F	KF-VE	'14.04-'14.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	LA310F	KF-VE	'14.07-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'98.10-'99.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'99.06-'00.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'00.10-'01.09	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	PSS(Power steering system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	SRS Airbag	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	AC(Air condition system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	MFD(Multi function display)	V			V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'01.10-'02.09	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	SYSTEM SEARCH																																			
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	PSS(Power steering system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	SRS Airbag	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	AC(Air condition system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	MFD(Multi function display)	V			V																															
International(- 2002)	PLEO	RA1	EN07 DOHC(S/C)	'02.10-'03.12	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	SYSTEM SEARCH																																			
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	PSS(Power steering system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	SRS Airbag	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	ODS(Occupant detection system)	V	V		V			V																												

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'98.10-'99.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'99.06-'00.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'00.10-'01.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'01.10-'02.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'02.10-'03.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'04.01-'05.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(N/A)	'05.10-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'98.10-'99.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	AC(Air condition system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	MFD(Multi function display)	V			V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'99.06-'00.09	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	SYSTEM SEARCH																																			
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	PSS(Power steering system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	SRS Airbag	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	AC(Air condition system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	MFD(Multi function display)	V			V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'00.10-'01.09	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	SYSTEM SEARCH																																			
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	PSS(Power steering system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	SRS Airbag	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	AC(Air condition system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	MFD(Multi function display)	V			V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'01.10-'02.09	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	SYSTEM SEARCH																																			
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	AT(Auto Transmission)	V	V		V									V	V	V	V																			

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'02.10-'03.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	Immobilizer																											V	V	V	V	V	V	V			
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'04.01-'05.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	Immobilizer																											V	V	V	V	V	V	V			
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA1	EN07 SOHC(S/C)	'05.10-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'99.06-'00.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'00.10-'01.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'01.10-'02.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 DOHC(S/C)	'02.10-'03.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'98.10-'99.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	Immobilizer																											V	V	V	V	V	V				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'99.06-'00.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'00.10-'01.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	ALW(Automatic light and wiper system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'01.10-'02.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'02.10-'03.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'04.01-'05.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	SRS Airbag	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(N/A)	'05.10-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'98.10-'99.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'99.06-'00.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	Engine	V	V		V						V	V	V																						V	V	V

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'00.10-'01.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'01.10-'02.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	AC(Air condition system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'02.10-'03.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'04.01-'05.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RA2	EN07 SOHC(S/C)	'05.10-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'98.10-'99.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'99.06-'00.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'00.10-'01.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'01.10-'02.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'02.10-'03.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	Meter(Combination meter)	V	V	V	V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'04.01-'05.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'05.10-'08.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV1	EN07 SOHC(N/A)	'08.08-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'98.10-'99.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'99.06-'00.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'00.10-'01.09	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'01.10-'02.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'02.10-'03.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'04.01-'05.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'05.10-'08.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	SYSTEM SEARCH																																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	PLEO	RV2	EN07 SOHC(N/A)	'08.08-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'04.12-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'05.11-'06.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'06.11-'07.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'07.06-'08.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ1	EN07 DOHC(N/A)	'08.06-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'05.11-'06.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'06.11-'07.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'07.06-'08.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ1	EN07 DOHC(S/C)	'08.06-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'04.12-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'05.11-'06.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ1	EN07 SOHC(N/A)	'06.11-'07.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'04.12-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'05.11-'06.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'06.11-'07.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'07.06-'08.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	Immobilizer																											V	V	V	V	V	V				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ2	EN07 DOHC(N/A)	'08.06-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'05.11-'06.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	ALW(Automatic light and wiper system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'06.11-'07.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'07.06-'08.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ2	EN07 DOHC(S/C)	'08.06-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	SRS Airbag	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'04.12-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'05.11-'06.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	SYSTEM SEARCH																																				
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	SRS Airbag	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	MFD(Multi function display)	V			V																																
International(- 2002)	R1	RJ2	EN07 SOHC(N/A)	'06.11-'07.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	Engine	V	V		V						V	V	V																						V	V	V

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'03.12-'04.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'04.11-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	AC(Air condition system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'05.11-'06.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'06.11-'07.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'07.06-'08.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 DOHC(N/A)	'08.06-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'03.12-'04.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'04.11-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'05.11-'06.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'06.11-'07.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	Meter(Combination meter)	V	V	V	V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'07.06-'08.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 DOHC(S/C)	'08.06-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'03.12-'04.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'04.11-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'05.11-'06.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'06.11-'07.05	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'07.06-'08.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	SYSTEM SEARCH																																				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC1	EN07 SOHC(N/A)	'08.06-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'03.12-'04.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'04.11-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'05.11-'06.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'06.11-'07.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'07.06-'08.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC2	EN07 DOHC(N/A)	'08.06-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'03.12-'04.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'04.11-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'05.11-'06.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'06.11-'07.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'07.06-'08.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 DOHC(S/C)	'08.06-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'03.12-'04.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'04.11-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'05.11-'06.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'06.11-'07.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'07.06-'08.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	SYSTEM SEARCH																																				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	SRS Airbag	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	AC(Air condition system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	MFD(Multi function display)	V			V																																
International(- 2002)	R2	RC2	EN07 SOHC(N/A)	'08.06-'10.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'90.02-'91.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'90.02-'91.07	Engine	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'91.08-'92.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'91.08-'92.08	Engine	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'91.08-'92.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'91.08-'92.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'92.09-'93.11	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'92.09-'93.11	Engine	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'92.09-'93.11	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'92.09-'93.11	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'93.12-'95.09	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'93.12-'95.09	Engine	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'95.10-'96.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'95.10-'96.08	Engine	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'96.09-'97.10	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'96.09-'97.10	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'97.11-'99.01	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'97.11-'99.01	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'97.11-'99.01	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(N/A)	'97.11-'99.01	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'90.02-'91.07	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'90.02-'91.07	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'91.08-'92.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'91.08-'92.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'91.08-'92.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'91.08-'92.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'92.09-'93.11	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'92.09-'93.11	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'92.09-'93.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'92.09-'93.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'93.12-'95.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'93.12-'95.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'95.10-'96.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'95.10-'96.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'96.09-'97.10	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'96.09-'97.10	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'97.11-'99.02	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'97.11-'99.02	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'97.11-'99.02	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV3	EN07 SOHC(S/C)	'97.11-'99.02	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'90.02-'91.07	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'90.02-'91.07	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'91.08-'92.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'91.08-'92.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'91.08-'92.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'91.08-'92.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'92.09-'93.11	SYSTEM SEARCH																																					

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'92.09-'93.11	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'92.09-'93.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'92.09-'93.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'93.12-'95.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'93.12-'95.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'95.10-'96.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'95.10-'96.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'96.09-'97.10	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'96.09-'97.10	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'97.11-'99.01	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'97.11-'99.01	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'97.11-'99.01	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(N/A)	'97.11-'99.01	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'90.02-'91.07	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'90.02-'91.07	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'91.08-'92.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'91.08-'92.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'91.08-'92.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'91.08-'92.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'92.09-'93.11	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'92.09-'93.11	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'92.09-'93.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'92.09-'93.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'93.12-'95.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'93.12-'95.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'95.10-'96.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'95.10-'96.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'96.09-'97.10	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'96.09-'97.10	Engine	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'97.11-'99.02	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'97.11-'99.02	Engine	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'97.11-'99.02	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR	KV4	EN07 SOHC(S/C)	'97.11-'99.02	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR	S321B	KF-DET	'12.04-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR	S321B	KF-DET	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR	S321B	KF-VE	'12.04-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR	S321B	KF-VE	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR	S331B	KF-DET	'12.04-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR	S331B	KF-DET	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR	S331B	KF-VE	'12.04-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR	S331B	KF-VE	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	Meter(Combination meter)	V	V	V	V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	AC(Air condition system)	V	V		V																																	
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	ALW(Automatic light and wiper system)	V	V		V																																	
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																												
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	MFD(Multi function display)	V			V																																	
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.02-'02.08	ASS(Auto start/stop)	V	V		V																																	
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'02.09-'03.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'03.11-'04.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'04.09-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'05.11-'08.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'08.07-'09.08	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(N/A)	'09.09-'12.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV1	EN07 SOHC(S/C)	'09.09-'12.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																		V	V	V												

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'02.09-'03.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'03.11-'04.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'04.09-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'05.11-'08.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	AC(Air condition system)	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	MFD(Multi function display)	V			V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'08.07-'09.08	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	SYSTEM SEARCH																																			
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	AC(Air condition system)	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	MFD(Multi function display)	V			V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(N/A)	'09.09-'12.03	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	SYSTEM SEARCH																																			
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	AC(Air condition system)	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	MFD(Multi function display)	V			V																															
International(- 2002)	SAMBAR	TV2	EN07 SOHC(S/C)	'09.09-'12.03	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'90.02-'91.07	SYSTEM SEARCH																																			
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'90.02-'91.07	Engine	V	V		V																															
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																															
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																															

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'91.08-'92.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'91.08-'92.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'91.08-'92.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'91.08-'92.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'92.10-'93.11	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'92.10-'93.11	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'92.10-'93.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'92.10-'93.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'93.12-'95.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'93.12-'95.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'95.10-'96.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'95.10-'96.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'96.09-'97.10	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'96.09-'97.10	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'97.11-'99.01	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'97.11-'99.01	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'97.11-'99.01	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(N/A)	'97.11-'99.01	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'90.02-'91.07	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'90.02-'91.07	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'91.08-'92.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'91.08-'92.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'91.08-'92.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'91.08-'92.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'92.10-'93.11	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'92.10-'93.11	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'92.10-'93.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'92.10-'93.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'93.12-'95.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'93.12-'95.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'95.10-'96.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'95.10-'96.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'96.09-'97.10	SYSTEM SEARCH																																					

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'96.09-'97.10	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'97.11-'99.01	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'97.11-'99.01	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'97.11-'99.01	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV3	EN07 SOHC(S/C)	'97.11-'99.01	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'90.02-'91.07	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'90.02-'91.07	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'91.08-'92.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'91.08-'92.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'91.08-'92.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'91.08-'92.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'92.10-'93.11	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'92.10-'93.11	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'92.10-'93.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'92.10-'93.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'93.12-'95.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'93.12-'95.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'95.10-'96.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'95.10-'96.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'96.09-'97.10	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'96.09-'97.10	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'97.11-'99.01	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'97.11-'99.01	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'97.11-'99.01	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(N/A)	'97.11-'99.01	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'90.02-'91.07	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'90.02-'91.07	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'91.08-'92.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'91.08-'92.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'91.08-'92.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'91.08-'92.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'92.10-'93.11	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'92.10-'93.11	Engine	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'92.10-'93.11	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'92.10-'93.11	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'93.12-'95.09	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'93.12-'95.09	Engine	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'95.10-'96.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'95.10-'96.08	Engine	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'96.09-'97.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'96.09-'97.10	Engine	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'97.11-'99.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'97.11-'99.01	Engine	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'97.11-'99.01	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	KV4	EN07 SOHC(S/C)	'97.11-'99.01	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(N/A)	'02.02-'02.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV1	EN07 SOHC(S/C)	'02.02-'02.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	ALW(Automatic light and wiper system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(N/A)	'02.02-'02.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	SRS Airbag	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS VAN	TV2	EN07 SOHC(S/C)	'02.02-'02.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'90.02-'91.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'90.02-'91.07	Engine	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'91.08-'92.09	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'91.08-'92.09	Engine	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'91.08-'92.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'91.08-'92.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'92.10-'93.11	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'92.10-'93.11	Engine	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'92.10-'93.11	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'92.10-'93.11	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'93.12-'95.09	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'93.12-'95.09	Engine	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV3	EN07 SOHC(N/A)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV4	EN07 SOHC(N/A)	'90.02-'91.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	KV4	EN07 SOHC(N/A)	'90.02-'91.07	Engine	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV4	EN07 SOHC(N/A)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV4	EN07 SOHC(N/A)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV4	EN07 SOHC(N/A)	'91.08-'92.09	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	KV4	EN07 SOHC(N/A)	'91.08-'92.09	Engine	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV4	EN07 SOHC(N/A)	'91.08-'92.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV4	EN07 SOHC(N/A)	'91.08-'92.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV4	EN07 SOHC(N/A)	'93.12-'95.09	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	KV4	EN07 SOHC(N/A)	'93.12-'95.09	Engine	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV4	EN07 SOHC(N/A)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	KV4	EN07 SOHC(N/A)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	AC(Air condition system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'02.09-'03.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'03.11-'04.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'04.09-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'05.11-'07.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'07.12-'08.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(N/A)	'08.07-'09.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'02.09-'03.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'03.11-'04.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'04.09-'05.10	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	AC(Air condition system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	MFD(Multi function display)	V			V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'05.11-'07.06	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	SYSTEM SEARCH																																			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	AC(Air condition system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	MFD(Multi function display)	V			V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'07.12-'08.06	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	SYSTEM SEARCH																																			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	ODS(Occupant detection system)	V	V		V			V																												

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW1	EN07 SOHC(S/C)	'08.07-'09.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'02.09-'03.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'03.11-'04.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'04.09-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'05.11-'07.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'07.12-'08.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(N/A)	'08.07-'09.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'02.09-'03.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	AC(Air condition system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	MFD(Multi function display)	V			V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'03.11-'04.08	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	SYSTEM SEARCH																																			
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	AC(Air condition system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	MFD(Multi function display)	V			V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'04.09-'05.10	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	SYSTEM SEARCH																																			
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	AC(Air condition system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	MFD(Multi function display)	V			V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'05.11-'07.06	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	SYSTEM SEARCH																																			
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	Immobilizer																											V	V	V	V	V	V			

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'07.12-'08.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR DIAS WAGON	TW2	EN07 SOHC(S/C)	'08.07-'09.12	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR OPENDECK	S321Q	KF-VE	'12.07-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR OPENDECK	S321Q	KF-VE	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR OPENDECK	S331Q	KF-VE	'12.07-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR OPENDECK	S331Q	KF-VE	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'90.02-'91.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'90.02-'91.07	Engine	V	V		V																																
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'91.08-'92.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'91.08-'92.08	Engine	V	V		V																																
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'91.08-'92.08	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'91.08-'92.08	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'92.09-'93.11	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'92.09-'93.11	Engine	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'92.09-'93.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'92.09-'93.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'93.12-'95.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'93.12-'95.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'95.10-'96.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'95.10-'96.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'96.09-'97.10	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'96.09-'97.10	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'97.11-'99.01	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'97.11-'99.01	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'97.11-'99.01	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(N/A)	'97.11-'99.01	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'90.02-'91.07	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'90.02-'91.07	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'91.08-'92.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'91.08-'92.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'91.08-'92.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'91.08-'92.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'92.09-'93.11	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'92.09-'93.11	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'92.09-'93.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'92.09-'93.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'93.12-'95.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'93.12-'95.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'95.10-'96.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'95.10-'96.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'96.09-'97.10	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'96.09-'97.10	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS3	EN07 SOHC(S/C)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'90.02-'91.07	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'90.02-'91.07	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'91.08-'92.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'91.08-'92.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'91.08-'92.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'91.08-'92.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'92.09-'93.11	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'92.09-'93.11	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'92.09-'93.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'92.09-'93.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'93.12-'95.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'93.12-'95.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'95.10-'96.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'95.10-'96.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'96.09-'97.10	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'96.09-'97.10	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'97.11-'99.01	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'97.11-'99.01	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'97.11-'99.01	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(N/A)	'97.11-'99.01	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'90.02-'91.07	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'90.02-'91.07	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'91.08-'92.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'91.08-'92.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'91.08-'92.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'91.08-'92.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'92.09-'93.11	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'92.09-'93.11	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'92.09-'93.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'92.09-'93.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'93.12-'95.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'93.12-'95.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'95.10-'96.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'95.10-'96.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'96.09-'97.10	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'96.09-'97.10	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'97.11-'99.01	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'97.11-'99.01	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'97.11-'99.01	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KS4	EN07 SOHC(S/C)	'97.11-'99.01	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'90.02-'91.07	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'90.02-'91.07	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'91.08-'92.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'91.08-'92.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'91.08-'92.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'91.08-'92.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'92.09-'93.11	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'92.09-'93.11	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'92.09-'93.11	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'92.09-'93.11	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'93.12-'95.09	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'93.12-'95.09	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'95.10-'96.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'95.10-'96.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'95.10-'96.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'95.10-'96.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'96.09-'97.10	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'96.09-'97.10	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'96.09-'97.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'96.09-'97.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'97.11-'99.01	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'97.11-'99.01	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'97.11-'99.01	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV3	EN07 SOHC(N/A)	'97.11-'99.01	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'90.02-'91.07	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'90.02-'91.07	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'90.02-'91.07	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'90.02-'91.07	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'91.08-'92.08	SYSTEM SEARCH																																					
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'91.08-'92.08	Engine	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'91.08-'92.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'91.08-'92.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'92.09-'93.11	SYSTEM SEARCH																																					

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'92.09-'93.11	Engine	V	V		V																																
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'92.09-'93.11	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'92.09-'93.11	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'93.12-'95.09	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'93.12-'95.09	Engine	V	V		V																																
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'93.12-'95.09	AT(Auto Transmission)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	KV4	EN07 SOHC(N/A)	'93.12-'95.09	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	S201H	KF-VE	'12.04-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR TRUCK	S201H	KF-VE	'14.04-'14.08	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR TRUCK	S201J	KF-VE	'12.04-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR TRUCK	S201J	KF-VE	'14.04-'14.08	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR TRUCK	S211H	KF-VE	'12.04-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR TRUCK	S211H	KF-VE	'14.04-'14.08	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR TRUCK	S211J	KF-VE	'12.04-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR TRUCK	S211J	KF-VE	'14.04-'14.08	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR TRUCK	S500J	KF-VE	'14.09-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR TRUCK	S510J	KF-VE	'14.09-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.02-'02.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'02.09-'03.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'03.11-'04.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'04.09-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'05.11-'08.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'08.07-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT1	EN07 SOHC(N/A)	'09.09-'12.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'02.09-'03.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'03.11-'04.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'04.09-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'05.11-'08.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'08.07-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	Immobilizer																											V	V	V	V	V	V				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(N/A)	'09.09-'12.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	SRS Airbag	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.02-'02.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'02.09-'03.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	ABS(Antilocked Braking System)	V	V		V																		V	V	V												
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'03.11-'04.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	Engine	V	V		V						V	V	V																						V	V	V

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	AC(Air condition system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	MFD(Multi function display)	V			V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'04.09-'05.10	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	SYSTEM SEARCH																																			
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	AC(Air condition system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	MFD(Multi function display)	V			V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'05.11-'08.06	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	SYSTEM SEARCH																																			
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	AC(Air condition system)	V	V		V																															

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'08.07-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TT2	EN07 SOHC(S/C)	'09.09-'12.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'99.02-'00.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.02-'02.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'02.09-'03.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	Meter(Combination meter)	V	V	V	V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'03.11-'04.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'04.09-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'05.11-'08.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'08.07-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV1	EN07 SOHC(N/A)	'09.09-'12.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.04-'00.10	ASS(Auto start/stop)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	AC(Air condition system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	MFD(Multi function display)	V			V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'00.11-'01.07	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	SYSTEM SEARCH																																			
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	ODS(Occupant detection system)	V	V		V			V																												
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	Meter(Combination meter)	V	V	V	V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	AC(Air condition system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	ALW(Automatic light and wiper system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	AHLS(Automatic headlight leveling system)	V	V		V				V	V																										
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	MFD(Multi function display)	V			V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'01.08-'02.01	ASS(Auto start/stop)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	SYSTEM SEARCH																																			
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	Immobilizer																											V	V	V	V	V	V			
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	AT(Auto Transmission)	V	V		V									V	V	V	V																			
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V										
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V													
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	PSS(Power steering system)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	SRS Airbag	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	BCM(Body Control Module)	V	V	V	V																						V	V								
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	TPM(Tire pressure monitor)	V	V		V																															
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	ODS(Occupant detection system)	V	V		V			V																												

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.02-'02.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'02.09-'03.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'03.11-'04.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'04.09-'05.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'05.11-'08.06	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'08.07-'09.08	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	SYSTEM SEARCH																																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	SRS Airbag	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	AC(Air condition system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	MFD(Multi function display)	V			V																																
International(- 2002)	SAMBAR TRUCK	TV2	EN07 SOHC(N/A)	'09.09-'12.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	LA100F	KF-DET	'11.05-'11.10	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA100F	KF-DET	'11.11-'12.12	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA100F	KF-DET	'13.01-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA100F	KF-DET	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA100F	KF-VE	'11.05-'11.10	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA100F	KF-VE	'11.11-'12.12	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA100F	KF-VE	'13.01-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA100F	KF-VE	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA110F	KF-DET	'11.05-'11.10	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA110F	KF-DET	'11.11-'12.12	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA110F	KF-DET	'13.01-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA110F	KF-DET	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA110F	KF-VE	'11.05-'11.10	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA110F	KF-VE	'11.11-'12.12	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA110F	KF-VE	'13.01-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	LA110F	KF-VE	'14.04-	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	ODS(Occupant detection system)	V	V		V			V																													

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'06.06-'07.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'07.11-'08.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'08.11-'09.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(N/A)	'09.11-'11.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'06.06-'07.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	MFD(Multi function display)	V			V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'07.11-'08.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'08.11-'09.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN1	EN07 DOHC(S/C)	'09.11-'11.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	TPM(Tire pressure monitor)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'06.06-'07.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'07.11-'08.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'08.11-'09.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(N/A)	'09.11-'11.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'06.06-'07.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'07.11-'08.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'08.11-'09.10	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	SYSTEM SEARCH																																				
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	PSS(Power steering system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	SRS Airbag	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	AC(Air condition system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	MFD(Multi function display)	V			V																																
International(- 2002)	STELLA	RN2	EN07 DOHC(S/C)	'09.11-'11.04	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	TRAVIQ	XM182	Z18 DOHC(N/A)	'03.07-'04.12	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	TRAVIQ	XM220	Z22 DOHC(N/A)	'01.08-'02.09	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	TRAVIQ	XM220	Z22 DOHC(N/A)	'02.10-'03.06	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	TRAVIQ	XM220	Z22 DOHC(N/A)	'03.07-'04.12	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	TREZIA	NCP120X	1NZ-FE	'10.11-'11.10	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	TREZIA	NCP120X	1NZ-FE	'11.11-'12.07	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	TREZIA	NCP120X	1NZ-FE	'12.08-'14.03	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	TREZIA	NCP120X	1NZ-FE	'14.04-'14.04	Please select the original manufacturer of the vehicle.																																				
International(- 2002)	TREZIA	NCP120X	1NZ-FE	'14.05-	Please select the original manufacturer of the vehicle.																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	TREZIA	NCP125X	1NZ-FE	'10.11-'11.10	Please select the original manufacturer of the vehicle.																																					
International(- 2002)	TREZIA	NCP125X	1NZ-FE	'11.11-'12.07	Please select the original manufacturer of the vehicle.																																					
International(- 2002)	TREZIA	NCP125X	1NZ-FE	'12.08-'14.03	Please select the original manufacturer of the vehicle.																																					
International(- 2002)	TREZIA	NCP125X	1NZ-FE	'14.04-'14.04	Please select the original manufacturer of the vehicle.																																					
International(- 2002)	TREZIA	NCP125X	1NZ-FE	'14.05-	Please select the original manufacturer of the vehicle.																																					
International(- 2002)	TREZIA	NSP120X	1NR-FE	'10.11-'11.10	Please select the original manufacturer of the vehicle.																																					
International(- 2002)	TREZIA	NSP120X	1NR-FE	'11.11-'12.07	Please select the original manufacturer of the vehicle.																																					
International(- 2002)	TREZIA	NSP120X	1NR-FE	'12.08-'14.03	Please select the original manufacturer of the vehicle.																																					
International(- 2002)	TREZIA	NSP120X	1NR-FE	'14.04-'14.04	Please select the original manufacturer of the vehicle.																																					
International(- 2002)	TREZIA	NSP120X	1NR-FKE	'14.05-	Please select the original manufacturer of the vehicle.																																					
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'92.03-'93.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'92.03-'93.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'92.03-'93.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'92.03-'93.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'93.09-'94.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'93.09-'94.04	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'93.09-'94.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'93.09-'94.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'94.05-'95.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'94.05-'95.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'94.05-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'94.05-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'95.10-'96.10	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'95.10-'96.10	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'95.10-'96.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'95.10-'96.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'96.11-'97.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'96.11-'97.04	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'96.11-'97.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'96.11-'97.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'97.05-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'97.05-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'97.05-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'97.05-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'97.09-'98.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'97.09-'98.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'97.09-'98.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 DOHC(S/C)	'97.09-'98.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'92.03-'93.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'92.03-'93.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'92.03-'93.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'92.03-'93.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'93.09-'94.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'93.09-'94.04	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'93.09-'94.04	AT(Auto Transmission)	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'93.09-'94.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'94.05-'95.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'94.05-'95.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'94.05-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'94.05-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'95.10-'96.10	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'95.10-'96.10	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'95.10-'96.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'95.10-'96.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'96.11-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'96.11-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'96.11-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'96.11-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'97.09-'98.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'97.09-'98.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'97.09-'98.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(N/A)	'97.09-'98.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'92.03-'93.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'92.03-'93.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'92.03-'93.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'92.03-'93.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'93.09-'94.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'93.09-'94.04	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'93.09-'94.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'93.09-'94.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'94.05-'95.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'94.05-'95.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'94.05-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'94.05-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'95.10-'96.10	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'95.10-'96.10	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'95.10-'96.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'95.10-'96.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'96.11-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'96.11-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'96.11-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK3	EN07 SOHC(S/C)	'96.11-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'92.03-'93.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'92.03-'93.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'92.03-'93.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'92.03-'93.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'93.09-'94.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'93.09-'94.04	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'93.09-'94.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'93.09-'94.04	ABS(Antilocked Braking System)	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'94.05-'95.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'94.05-'95.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'94.05-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'94.05-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'95.10-'96.10	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'95.10-'96.10	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'95.10-'96.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'95.10-'96.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'96.11-'97.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'96.11-'97.04	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'96.11-'97.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'96.11-'97.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'97.05-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'97.05-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'97.05-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'97.05-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'97.09-'98.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'97.09-'98.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'97.09-'98.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 DOHC(S/C)	'97.09-'98.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'92.03-'93.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'92.03-'93.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'92.03-'93.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'92.03-'93.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'93.09-'94.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'93.09-'94.04	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'93.09-'94.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'93.09-'94.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'94.05-'95.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'94.05-'95.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'94.05-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'94.05-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'95.10-'96.10	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'95.10-'96.10	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'95.10-'96.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'95.10-'96.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'96.11-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'96.11-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'96.11-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'96.11-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'97.09-'98.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'97.09-'98.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'97.09-'98.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(N/A)	'97.09-'98.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'92.03-'93.08	SYSTEM SEARCH																																					

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'92.03-'93.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'92.03-'93.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'92.03-'93.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'93.09-'94.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'93.09-'94.04	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'93.09-'94.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'93.09-'94.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'94.05-'95.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'94.05-'95.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'94.05-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'94.05-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'95.10-'96.10	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'95.10-'96.10	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'95.10-'96.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'95.10-'96.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'96.11-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'96.11-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'96.11-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KK4	EN07 SOHC(S/C)	'96.11-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'92.03-'93.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'92.03-'93.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'92.03-'93.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'92.03-'93.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'93.09-'94.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'93.09-'94.04	Engine	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'93.09-'94.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'93.09-'94.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'94.05-'95.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'94.05-'95.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'94.05-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'94.05-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'95.10-'96.10	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'95.10-'96.10	Engine	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'95.10-'96.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'95.10-'96.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'96.11-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'96.11-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'96.11-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'96.11-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'97.09-'98.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'97.09-'98.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'97.09-'98.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KW3	EN07 SOHC(N/A)	'97.09-'98.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'92.03-'93.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'92.03-'93.08	Engine	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'92.03-'93.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'92.03-'93.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'93.09-'94.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'93.09-'94.04	Engine	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'93.09-'94.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'93.09-'94.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'94.05-'95.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'94.05-'95.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'94.05-'95.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'94.05-'95.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'95.10-'96.10	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'95.10-'96.10	Engine	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'95.10-'96.10	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'95.10-'96.10	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'96.11-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'96.11-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'96.11-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'96.11-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'97.09-'98.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'97.09-'98.09	Engine	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'97.09-'98.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO	KW4	EN07 SOHC(N/A)	'97.09-'98.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 DOHC(S/C)	'96.10-'97.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK3	EN07 DOHC(S/C)	'96.10-'97.04	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 DOHC(S/C)	'96.10-'97.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 DOHC(S/C)	'96.10-'97.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 DOHC(S/C)	'97.05-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK3	EN07 DOHC(S/C)	'97.05-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 DOHC(S/C)	'97.05-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 DOHC(S/C)	'97.05-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 DOHC(S/C)	'97.09-'98.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK3	EN07 DOHC(S/C)	'97.09-'98.09	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 DOHC(S/C)	'97.09-'98.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 DOHC(S/C)	'97.09-'98.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'95.11-'96.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'95.11-'96.04	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'95.11-'96.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'95.11-'96.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'96.05-'96.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'96.05-'96.09	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'96.05-'96.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'96.05-'96.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'96.10-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'96.10-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'96.10-'97.08	AT(Auto Transmission)	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'96.10-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'97.09-'98.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'97.09-'98.09	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'97.09-'98.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(N/A)	'97.09-'98.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(S/C)	'96.10-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(S/C)	'96.10-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(S/C)	'96.10-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(S/C)	'96.10-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(S/C)	'97.09-'98.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(S/C)	'97.09-'98.09	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(S/C)	'97.09-'98.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK3	EN07 SOHC(S/C)	'97.09-'98.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 DOHC(S/C)	'96.10-'97.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK4	EN07 DOHC(S/C)	'96.10-'97.04	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 DOHC(S/C)	'96.10-'97.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 DOHC(S/C)	'96.10-'97.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 DOHC(S/C)	'97.05-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK4	EN07 DOHC(S/C)	'97.05-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 DOHC(S/C)	'97.05-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 DOHC(S/C)	'97.05-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 DOHC(S/C)	'97.09-'98.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK4	EN07 DOHC(S/C)	'97.09-'98.09	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 DOHC(S/C)	'97.09-'98.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 DOHC(S/C)	'97.09-'98.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'95.11-'96.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'95.11-'96.04	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'95.11-'96.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'95.11-'96.04	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'96.05-'96.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'96.05-'96.09	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'96.05-'96.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'96.05-'96.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'96.10-'97.08	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'96.10-'97.08	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'96.10-'97.08	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'96.10-'97.08	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'97.09-'98.09	SYSTEM SEARCH																																					
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'97.09-'98.09	Engine	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'97.09-'98.09	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO BISTRO	KK4	EN07 SOHC(N/A)	'97.09-'98.09	ABS(Antilocked Braking System)	V	V		V																																	
International(- 2002)	VIVIO TARGATOP	KY3	EN07 SOHC(N/A)	'93.05-'94.04	SYSTEM SEARCH																																					
International(- 2002)	VIVIO TARGATOP	KY3	EN07 SOHC(N/A)	'93.05-'94.04	Engine	V	V		V																																	
International(- 2002)	VIVIO TARGATOP	KY3	EN07 SOHC(N/A)	'93.05-'94.04	AT(Auto Transmission)	V	V		V																																	
International(- 2002)	VIVIO TARGATOP	KY3	EN07 SOHC(N/A)	'93.05-'94.04	ABS(Antilocked Braking System)	V	V		V																																	

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	VIVIO TARGATOP	KY3	EN07 SOHC(S/C)	'93.05-'94.04	SYSTEM SEARCH																																				
International(- 2002)	VIVIO TARGATOP	KY3	EN07 SOHC(S/C)	'93.05-'94.04	Engine	V	V		V																																
International(- 2002)	VIVIO TARGATOP	KY3	EN07 SOHC(S/C)	'93.05-'94.04	AT(Auto Transmission)	V	V		V																																
International(- 2002)	VIVIO TARGATOP	KY3	EN07 SOHC(S/C)	'93.05-'94.04	ABS(Antilocked Braking System)	V	V		V																																
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	SYSTEM SEARCH																																				
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	PSS(Power steering system)	V	V		V																																
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	SRS Airbag	V	V		V																																
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	AC(Air condition system)	V	V		V																																
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	MFD(Multi function display)	V			V																																
International(- 2002)	WRX	VAB	EJ20 DOHC(T/C)	'14.08-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	SYSTEM SEARCH																																				
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	PSS(Power steering system)	V	V		V																																
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	SRS Airbag	V	V		V																																
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	AC(Air condition system)	V	V		V																																
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	MFD(Multi function display)	V			V																																
International(- 2002)	WRX	VAG	FA20 DOHC(T/C)	'14.08-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	SYSTEM SEARCH																																				
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	PSS(Power steering system)	V	V		V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	SRS Airbag	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	AC(Air condition system)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	MFD(Multi function display)	V			V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'12.09-'13.05	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	SYSTEM SEARCH																																				
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	SRS Airbag	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	AC(Air condition system)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	MFD(Multi function display)	V			V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.06-'13.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	SYSTEM SEARCH																																				
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	Engine	V	V		V						V	V	V																					V	V	V
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	Immobilizer																												V	V	V	V	V	V			
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	AC(Air condition system)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	MFD(Multi function display)	V			V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'13.10-'14.03	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	SYSTEM SEARCH																																				

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	PSS(Power steering system)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	SRS Airbag	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	AC(Air condition system)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	MFD(Multi function display)	V			V																																
International(- 2002)	XV	GP7	FB20 DOHC(N/A)	'14.04-	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	SYSTEM SEARCH																																				
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	PSS(Power steering system)	V	V		V																																
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	SRS Airbag	V	V		V																																
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	Meter(Combination meter)	V	V	V	V																																
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	AC(Air condition system)	V	V		V																																
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	ALW(Automatic light and wiper system)	V	V		V																																
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	AHLS(Automatic headlight leveling system)	V	V		V				V	V																											
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	MFD(Multi function display)	V			V																																
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.06-'13.09	ASS(Auto start/stop)	V	V		V																																
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	SYSTEM SEARCH																																				
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	Immobilizer																											V	V	V	V	V	V				
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	AT(Auto Transmission)	V	V		V									V	V	V	V																				
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	ABS(Antilocked Braking System)	V	V		V																			V	V	V											
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V														
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	PSS(Power steering system)	V	V		V																																
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	SRS Airbag	V	V		V																																
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	BCM(Body Control Module)	V	V	V	V																						V	V									
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	TPM(Tire pressure monitor)	V	V		V																																
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	ODS(Occupant detection system)	V	V		V			V																													
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	Meter(Combination meter)	V	V	V	V																																

Vehicle	Model1	Model2	ENG type	Year	System	DTC Analysis	Data Analysis	Actuator	ECU Information Display	Re-Zeroing	Variable compressor break in drive	Transmitter ID Registration	Sensor initial setting	Auto light sensitivity adjustment	Service reset	Engine oil change	DPF regeneration	AT bleeding mode	AT learning mode	AWD ON/OFF switching mode	Rear differential inspection mode	Force sensor calibration mode	Break in parking brake drive mode	Parking brake removal mode	Clutch engagement position setting	Clutch sensor calibration mode	Parameter initialization mode	ABS Sequence Control Mode	VDC Check Mode	Set Mode Str. A. Sen. N and Lat. G Sen. 0P	Function Check	Integ. Unit customizing	Program Keys	Read number of registered keys	Erase keys	Engine ECU registration	Meter/SCU registration	Remote control engine starter registration	Ignition timing adjustment	Idle adjustment with A/C off	Idle adjustment with A/C on
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	AC(Air condition system)	V	V		V																																	
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	ALW(Automatic light and wiper system)	V	V		V																																	
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	AHLS(Automatic headlight leveling system)	V	V		V				V	V																												
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	MFD(Multi function display)	V			V																																	
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'13.10-'14.03	ASS(Auto start/stop)	V	V		V																																	
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	SYSTEM SEARCH																																					
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	Engine	V	V		V						V	V	V																						V	V	V
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	Immobilizer																												V	V	V	V	V	V				
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	AT(Auto Transmission)	V	V		V									V	V	V	V																					
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	ABS(Antilocked Braking System)	V	V		V																			V	V	V												
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	EPB(Electonic parking brake)	V	V		V													V	V	V	V	V	V															
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	PSS(Power steering system)	V	V		V																																	
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	SRS Airbag	V	V		V																																	
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	BCM(Body Control Module)	V	V	V	V																						V	V										
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	TPM(Tire pressure monitor)	V	V		V																																	
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	ODS(Occupant detection system)	V	V		V			V																														
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	Meter(Combination meter)	V	V	V	V																																	
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	AC(Air condition system)	V	V		V																																	
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	ALW(Automatic light and wiper system)	V	V		V																																	
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	AHLS(Automatic headlight leveling system)	V	V		V				V	V																												
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	MFD(Multi function display)	V			V																																	
International(- 2002)	XV HYBRID	GPE	FB20 DOHC(N/A)	'14.04-	ASS(Auto start/stop)	V	V		V																																	

System 1	DTC Analysis	Data Analysis	Actuator	ECU Information	VIN Registration	Vehicle variant registration	Read Injector Calibration Code	Replace ECM	Replace Injector	Injector calibration code	Replace catalyst converter(W/ DPF)	Replace DPF(W/ DPF)	Replace differential pressure sensor(W/ DPF)	Reset oil pressure light(W/ DPF)	DPF Regeneration(W/ DPF)	Replace MAF sensor(Reset A/F data)(W/O DPF)	Replace A/F sensor(W/O DPF)	Initialize EGR valve data	Initialize inlet throttle valve data	Initiallize diesel PF data	DPF Regeneration	Replace EGR	Replace Inlet throttle valve	AT Learning Value Initialization	CVT Oil Level Adjust	CVT Learning Value Setting	Learning Value Clear	CVT G Sensor Calibration	Hydraulic Control Test	Sensor Calibration	ESP Function Setting	Airbag Setting	Keyless Start System Function	Answer-Back Setting (Buzzer Sounding Outside Vehicle)	Warning Buzzer: Portable Remote Conotroller Outside Detection-Range	Warning: Portable Remote Conotroller Battery Low	Security Alarm Setting	Answer-Back Setting	Cornering Light Setting	Warning: Parking Brake Return Operation Undone	Turn Signal Lamp Setting	Remote Folding Mirror Setting	Slope sensor initialization	Vehicle Height Sensor Initialization	ID Code Read	Immobilizer	Key	Register New Ignition Key(Fix Code)	Immobilizer Change(Register SK Code)	ECM Change(Register SKC/PWD)	ECU Reset	Reset Immobilize	Immobilizer Information	Key Register	TPS ID Registration	Aiming
EPI(Engine/AT)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																																			
CNG/LPG	V	V		V																																																					
AT(CVT)	V	V	V	V																				V	V	V	V	V																													
ABS(VST/ESP)	V	V	V	V																									V	V	V																										
EPS(Electric Power Steering)	V	V		V																																																				
SRS Airbag	V	V		V																												V																									
SRS Airbag (8E)	V	V		V																																																				
SRS Airbag	V	V		V																																																				
Air Conditioner	V	V		V																																																				
BCM(Body Control Module)	V	V	V	V																													V	V	V	V	V	V	V	V	V	V														
EMCD(Electro Magnetic Control Device)	V	V		V																																																				
4WD(4 Wheel Drive)	V	V		V																																																				
Meter	V	V	V	V																																																				
Keyless Start	V	V		V																																																				
ACC(Auto Cruise Control System)	V			V																																																				
EV_Motor	V	V		V																																																				
TPMS(Tire Pressure Monitoring System)	V	V		V																																																			V	
Radar Brake Support	V	V		V																																																				V
Lighting and Turn Signal	V	V		V																																																				
Immobilizer	V	V		V																																								V	V	V	V	V	V	V	V	V	V			
Idling Stop	V			V																																						V														
Auxiliary Power Module	V	V		V																																																				
Auto Leveling	V			V																																							V													

System 1	Guide Me Light to Car	Guide Me Light to Home	Auto Drive Lock	Auto Drive Unlock	Shock Sensor	Foot Light	Daytime Running Light	Door Unlock	Shock Sensor Pre-warn Sensitivity	Shock Sensor Full Blast Sensitivity	Keyless Start System	Remote Controller Battery Warning	Answer-Back (Outside Buzzer)	Remote Controller Area Warning	Initialize Clutch and Transaxle	Clutch Clamp Position Control	Clutch Adjustment Control	Initialize Clutch	Initialize Transaxle	Oil Change Request Light Initialization	Oil Change Request Light	Oil Change Conditions	Starter Driving Counter Registration	Starter Driving Counter Reset
EPI(Engine/AT)																								
CNG/LPG																								
AT(CVT)															V	V	V	V	V					
ABS(VST/ESP)																								
EPS(Electric Power Steering)																								
SRS Airbag																								
SRS Airbag (8E)																								
SRS Airbag																								
Air Conditioner																								
BCM(Body Control Module)	V	V	V	V	V	V	V	V	V	V														
EMCD(Electro Magnetic Control Device)																								
4WD(4 Wheel Drive)																								
Meter																				V	V	V		
Keyless Start											V	V	V	V										
ACC(Auto Cruise Control System)																								
EV_Motor																								
TPMS(Tire Pressure Monitoring System)																								
Radar Brake Support																								
Lighting and Turn Signal																								
Immobilizer																								
Idling Stop																							V	V
Auxiliary Power Module																								
Auto Leveling																								

Model	System1	System2	DTC Analysis	Data Analysis	Data Analysis	System Identification	After Sale Data	Air Bleeding	ECU Reset	Flywheel 60 2 Tooth Flywheel	I2C Read	Injector Write	Leak Detection Test	Multijet Adaptive Control 1	Multijet Adaptive Control 2	Read C2I Data	Read ECU Parameter	Small Injection Correction 1	Small Injection Correction 2 Injector In Cylinder	VIN Write	Write C2I Data	Write Data
POWERTRAIN	EMS MPFI PETROL	ALL	V	V	V	V			V													
POWERTRAIN	EMS MPFI LPG	ALL	V	V	V	V																
POWERTRAIN	DRID/DICOR	ALL	V	V	V	V							V			V				V	V	
POWERTRAIN	EMS(DPCN) (TEST Version)	ALL	V	V	V	V	V															
POWERTRAIN	INDIGO ECS CR4 (TEST Version)	BS4	V	V	V	V																
POWERTRAIN	VISTA/MANZA DIESEL	ALL	V	V	V	V			V	V	V	V		V	V			V	V			
POWERTRAIN	VISTA/MANZA PETROL	ALL	V	V	V	V																
POWERTRAIN	NANO	ALL	V	V	V	V			V													
POWERTRAIN	XENON	ALL	V	V	V	V							V			V				V	V	
CHASSIS	ABS	VISTA/MANZA	V	V	V	V		V														
CHASSIS	ABS	SAFARI	V	V	V	V		V									V					V
BODY	SRS	SAFARI SRS1	V																			
BODY	SRS	SAFARI SRS2	V																			
BODY	SRS	VISTA/MANZA	V			V																
BODY	BCM	VISTA/MANZA	V	V	V	V																
BODY	BCM	OTHER	V	V	V	V																
ARIA	Diesel	EMS (Engine Management System)	V			V																
ARIA	Diesel	BCM (Body Control Management System)	V			V																
ARIA	Diesel	ABS (Anti-Lock Braking System)	V			V																
ARIA	Diesel	RPS (Reverse Parking System)	V			V																
ARIA	Diesel	WWC (Window Winder Control System)	V			V																
STORME	Diesel	EMS (Engine Management System)	V			V																
STORME	Diesel	EMS (Engine Management System)	V			V																
STORME	Diesel	BCM (Body Control Management System)	V			V																
STORME	Diesel	WWC (Window Winder Control System)	V			V																
SUMO	Diesel	EMS (Engine Management System)	V			V																

Year	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	AT/CVT Learning Value Initialization	G Sensor 0 Point Learning Start	CVT Hydraulic Pressure Learning Start	Injector ID Check	Injector Compensation	Injector Class Verification	Injector Class Set	Supply Pump Initializtion	AT Learning Value Initialization	DPF deterioration record clear	A/F sensor compensation Reset	Crank time compensation reset	Catalyst record clear	Parts exchange	Air Bleeder	[VSC Actuator]Intake System Air Bleeder	[VSC Actuator]Decompression System Air Bleeder	[ECB]Brake Control Prohibition	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialize	Back Up Memory Clear	VSC System 0 Point Clear	Torque sensor adjustment	Rotational Angle Sensor Calibration	Steering angle adjust	Key code erasure	Key code registration	Servo motor initialization	Wireless code erasure	Wireless code registration	Reset Memory	Body control module Initialization	Communication check	System Identification	Initializtion of immobilizer	Auto Registration Closure	Test Mode	Check Mode	Maintenance Mode 2WD (Exhaust Measurement)	Maintenance Mode 2WD (TRC Forbidden)	Maintenance Mode 4WD (Exhaust Measurement)	Maintenance Mode 4WD (TRC Forbidden)	Maintenance Mode 2WD	Maintenance Mode 4WD	Battery Control Data Initialization	Vehicle Mileage Write	Clutch Adjust Count	Pilot Quantity Learning(Detail)	Pilot Quantity Learning	Pilot Quantity Learning Values Reset	Pilot Quantity Learning Values Clear	Catalyst Record Read/Write	Catalyst Record Transferring
16PIN CONNECTOR	TCCS(Engine/AT)	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V																		V			V				V							V		V	V	V	V	V	V
16PIN CONNECTOR	TCCS2(Engine/AT)	V	V																																																							
16PIN CONNECTOR	Transmission(ECT/SMT/MMT)	V	V	V	V	V	V													V	V																V							V								V					
16PIN CONNECTOR	Hybrid Vehicle	V	V	V	V																																V							V	V	V	V	V	V	V	V						
16PIN CONNECTOR	Mild Hybrid Vehicle	V	V																																																							
16PIN CONNECTOR	Hybrid Vehicle Battery	V	V	V	V																																																					
16PIN CONNECTOR	ABS/VSC	V	V	V	V																V	V	V	V	V	V	V	V	V														V															
16PIN CONNECTOR	ABS/VSC/ARS	V	V	V	V																V							V															V															
16PIN CONNECTOR	Air Suspension/TEMS/AHC	V	V	V	V																																																					
16PIN CONNECTOR	Stabilizer	V	V																																																							
16PIN CONNECTOR	Electric Parking Brake	V	V	V	V																																V																					
16PIN CONNECTOR	ARS(Active Rear Steer)	V	V	V	V																																																					
16PIN CONNECTOR	SRS Airbag	V	V	V																																																						
16PIN CONNECTOR	4WD(4 Wheel Drive)	V	V	V	V																																V																					
16PIN CONNECTOR	EPS(Electric Power Steering)	V	V	V																										V	V																												
16PIN CONNECTOR	Radar Cruise Control	V	V	V																																																						
16PIN CONNECTOR	Radar Cruise Control(HV)	V	V	V																																																						
16PIN CONNECTOR	Stop And Go	V	V	V	V																																																					
16PIN CONNECTOR	VGRS(Variable Gear Ratio Steering)	V	V	V																												V																											
16PIN CONNECTOR	Immobiliser	V	V	V	V	V																											V	V								V	V															
16PIN CONNECTOR	Precrash Safety System	V	V	V	V																																																					
16PIN CONNECTOR	IPA(Intelligent Parking Assist)	V	V	V																																																						
16PIN CONNECTOR	Combination meter	V	V	V	V																																																					
16PIN CONNECTOR	EMS(Energy Management System)	V	V																																																							
16PIN CONNECTOR	Motor Generator	V	V	V																																																						
16PIN CONNECTOR	LKA(Lane Keeping Assist)	V	V																																																							
16PIN CONNECTOR	Active Stabilizer(Front)	V	V																																																							
16PIN CONNECTOR	Active Stabilizer(Rear)	V	V																																																							
16PIN CONNECTOR	Lane Departure Alert	V	V	V	V																																																					
16PIN CONNECTOR	Front Recognition Camera	V	V	V	V																																																					
16PIN CONNECTOR	Transmission Control	V	V	V																																																						
16PIN CONNECTOR	E-ACM(Electric Active Mount)	V	V	V	V																																																					
16PIN CONNECTOR	FCHV(Fuel Cell Hybrid Vehicle)		V		V																																																					
16PIN CONNECTOR	Vehicle Control	V	V	V	V																																																					
16PIN CONNECTOR	Grill Shutter	V	V	V	V																																																					
16PIN CONNECTOR	Plug-in Control(HV)	V	V	V																																									V													
16PIN CONNECTOR	KDSS(Kinetic Dynamic Suspension)	V	V	V	V																																																					
16PIN CONNECTOR	Tire Pressure Warning System	V	V	V																																																						
16PIN CONNECTOR	Charging Control	V	V	V	V																																																					
16PIN CONNECTOR	Starting Control	V	V	V	V																																																					
16PIN CONNECTOR	Gateway	V	V																																																							
16PIN CONNECTOR	Body	V	V	V	V																															V		V																					
16PIN CONNECTOR	Body No.2	V	V																																																							

Year	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	AT/CVT Learning Value Initialization	G Sensor 0 Point Learning Start	CVT Hydraulic Pressure Learning Start	Injector ID Check	Injector Compensation	Injector Class Verification	Injector Class Set	Supply Pump Initializtion	AT Learning Value Initialization	DPF deterioration record clear	A/F sensor compensation Reset	Crank time compensation reset	Catalyst record clear	Parts exchange	Air Bleeder	[VSC Actuator]Intake System Air Bleeder	[VSC Actuator]Decompression System Air Bleeder	[ECB]Brake Control Prohibition	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialize	Back Up Memory Clear	VSC System 0 Point Clear	Torque sensor adjustment	Rotational Angle Sensor Calibration	Steering angle adjust	Key code erasure	Key code registration	Servo motor initialization	Wireless code erasure	Wireless code registration	Reset Memory	Body control module Initialization	Communication check	System Identification	Initializtion of immobilizer	Auto Registration Closure	Test Mode	Check Mode	Maintenance Mode 2WD (Exhaust Measurement)	Maintenance Mode 2WD (TRC Forbidden)	Maintenance Mode 4WD (Exhaust Measurement)	Maintenance Mode 4WD (TRC Forbidden)	Maintenance Mode 2WD	Maintenance Mode 4WD	Battery Control Data Initialization	Vehicle Mileage Write	Clutch Adjust Count	Pilot Quantity Learning(Detail)	Pilot Quantity Learning	Pilot Quantity Learning Values Reset	Pilot Quantity Learning Values Clear	Catalyst Record Read/Write	Catalyst Record Transferring
16PIN CONNECTOR	Body No.3	V	V	V	V																																																													
16PIN CONNECTOR	Body No.4	V	V	V	V																																																												
16PIN CONNECTOR	Body No.5	V	V	V	V																																																												
16PIN CONNECTOR	Hybrid Gateway	V	V																																																														
16PIN CONNECTOR	ECB Gateway	V	V	V																																																													
16PIN CONNECTOR	ECM Gateway	V	V	V																																																													
16PIN CONNECTOR	PM1 gateway	V	V	V																																																													
16PIN CONNECTOR	PM2 gateway	V	V	V																																																													
16PIN CONNECTOR	Accessory Gateway	V	V																																																														
16PIN CONNECTOR	Master Switch	V	V	V	V																																																												
16PIN CONNECTOR	Combination Switch	V	V	V																																																													
16PIN CONNECTOR	Rear Console Switch	V	V																																																														
16PIN CONNECTOR	Air Conditioner	V	V	V	V																														V																															
16PIN CONNECTOR	Tilt And Telescopic	V	V	V	V																																																												
16PIN CONNECTOR	Driver Door(Mirror)	V	V	V	V																																																												
16PIN CONNECTOR	Passenger Door	V	V	V	V																																																												
16PIN CONNECTOR	Rear Right Door	V	V	V	V																																																												
16PIN CONNECTOR	Rear Left Door	V	V	V	V																																																												
16PIN CONNECTOR	Back Door	V	V	V	V																																																												
16PIN CONNECTOR	Driver Door Motor	V	V	V	V																																	V																										
16PIN CONNECTOR	Passenger Door Motor	V	V	V	V																																	V																										
16PIN CONNECTOR	Rear Right Door Motor	V	V	V	V																																	V																										
16PIN CONNECTOR	Rear Left Door Motor	V	V	V	V																																	V																										
16PIN CONNECTOR	Driver Seat	V	V	V	V																																																												
16PIN CONNECTOR	Passenger Seat	V	V	V	V																																																												
16PIN CONNECTOR	Rear Right Seat	V	V	V	V																																																												
16PIN CONNECTOR	Rear Left Seat	V	V	V	V																																																												
16PIN CONNECTOR	Driver Seat Switch	V	V	V	V																																																												
16PIN CONNECTOR	Rear Right Seat Switch	V	V																																																														
16PIN CONNECTOR	Front Right Seat A/C	V	V	V	V																																																												
16PIN CONNECTOR	Front Left Seat A/C	V	V	V	V																																																												
16PIN CONNECTOR	Rear Right Seat A/C	V	V	V	V																																																												
16PIN CONNECTOR	Rear Left Seat A/C	V	V	V	V																																																												
16PIN CONNECTOR	Slide Roof	V	V	V	V																																																												
16PIN CONNECTOR	Rain Sensor	V	V	V																																																													
16PIN CONNECTOR	Wiper			V	V																																																													
16PIN CONNECTOR	Occupant Detection	V	V	V																																																													
16PIN CONNECTOR	Night View	V	V																																																														
16PIN CONNECTOR	Steering Pad(Pad Switch)	V	V	V																																																													
16PIN CONNECTOR	Power Source Control	V	V	V	V																																																												
16PIN CONNECTOR	Electric Power Control	V	V																																																														
16PIN CONNECTOR	Entry And Start	V	V	V	V																													V	V					V																										
16PIN CONNECTOR	Theft Deterrent System	V	V	V	V																																																												

Year	System	DTC Analysis	DTC EraseMemory	Data Analysis	Actuation Test	ECU Information Display	AT/CVT Learning Value Initialization	G Sensor 0 Point Learning Start	CVT Hydraulic Pressure Learning Start	Injector ID Check	Injector Compensation	Injector Class Verification	Injector Class Set	Supply Pump Initializtion	AT Learning Value Initialization	DPF deterioration record clear	A/F sensor compensation Reset	Crank time compensation reset	Catalyst record clear	Parts exchange	Air Bleeder	[VSC Actuator]Intake System Air Bleeder	[VSC Actuator]Decompression System Air Bleeder	[ECB]Brake Control Prohibition	Accumulator 0 Down Drive	Yaw Rate / G Sensor 0 Point Clear (For ECB)	Linear Valve Learning Value Initialize	Back Up Memory Clear	VSC System 0 Point Clear	Torque sensor adjustment	Rotational Angle Sensor Calibration	Steering angle adjust	Key code erasure	Key code registration	Servo motor initialization	Wireless code erasure	Wireless code registration	Reset Memory	Body control module Initialization	Communication check	System Identification	Initializtion of immobilizer	Auto Registration Closure	Test Mode	Check Mode	Maintenance Mode 2WD (Exhaust Measurement)	Maintenance Mode 2WD (TRC Forbidden)	Maintenance Mode 4WD (Exhaust Measurement)	Maintenance Mode 4WD (TRC Forbidden)	Maintenance Mode 2WD	Maintenance Mode 4WD	Battery Control Data Initialization	Vehicle Mileage Write	Clutch Adjust Count	Pilot Quantity Learning(Detail)	Pilot Quantity Learning	Pilot Quantity Learning Values Reset	Pilot Quantity Learning Values Clear	Catalyst Record Read/Write	Catalyst Record Transferring
16PIN CONNECTOR	Clearance Sonar	V	V	V	V																																																											
16PIN CONNECTOR	Retractable Hard Top	V	V																																																													
16PIN CONNECTOR	Left Seat Mirror	V	V	V	V																																																											
16PIN CONNECTOR	Right Seat Mirror	V	V	V	V																																																											
16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)	V	V	V	V																																																											
16PIN CONNECTOR	WIL Gateway	V	V																																																													
16PIN CONNECTOR	Remote Security	V	V																																																													
16PIN CONNECTOR	Driver Seat Act Headrest	V	V																																																													
16PIN CONNECTOR	Help Net Gateway	V	V																																																													
16PIN CONNECTOR	Central Gateway	V	V	V																																																												
16PIN CONNECTOR	Precrash 2	V	V	V	V																																																											
16PIN CONNECTOR	Passenger Seat Act Headrest	V	V																																																													
16PIN CONNECTOR	Navigation System	V	V																																																													
16PIN CONNECTOR	Remote Engine Starter	V	V	V																																																												
16PIN CONNECTOR	Panoramic View Monitor	V	V	V																																																												
16PIN CONNECTOR	Blind Spot Monitor Master	V	V	V																																																												
16PIN CONNECTOR	Blind Spot Monitor Slave	V	V	V																																																												
16PIN CONNECTOR	Active Sound Control	V	V	V	V																																																											
16PIN CONNECTOR	Multi Bus Gateway	V	V																																																													
16PIN CONNECTOR	Multi Bus Monitor1	V	V																																																													
16PIN CONNECTOR	Multi Bus Monitor2	V	V																																																													
16PIN CONNECTOR	Vehicle Proximity Notification	V	V	V	V																																																											
17PIN CONNECTOR	ALL(DTC)	V																																																														
17PIN CONNECTOR	ALL(DTC/CURR)	V		V																																																												
17PIN CONNECTOR	ECT(AT)	V																																																														
17PIN CONNECTOR	Vacuum ABS	V																																																														
17PIN CONNECTOR	Vacuum ABS/TRC/4WD	V																																																														
17PIN CONNECTOR	Hydraulic ABS/VSC/4WD	V																																																														
17PIN CONNECTOR	4WD	V																																																														
17PIN CONNECTOR	TEMS(PIEZO/SKYHOOK)	V																																																														
17PIN CONNECTOR	Air Suspension System	V																																																														
17PIN CONNECTOR	Active Suspension System	V																																																														
17PIN CONNECTOR	TRC(Traction Control System)	V																																																														
17PIN CONNECTOR	VSC(Vehicle Stability Control)	V																																																														
17PIN CONNECTOR	Cruise	V																																																														
17PIN CONNECTOR	Airbag	V																																																														
17PIN CONNECTOR	Side Airbag	V																																																														
17PIN CONNECTOR	Air Conditioner	V																																																														
17PIN CONNECTOR	4WS(4 Wheele Steering)	V																																																														
17PIN CONNECTOR	ETCS(Electronic Throttle Control System)	V																																																														

Year	System	A/T Code Reset	Inspection Mode	ECU Information Sync	ID Registration	Onboard Equalizing Charge(beta)	SOC(STATUS OF CHARGING) SET(beta)	V80 Control SET(beta)	Zero Point Calibration	Key Code Reset(ECU Relearn)	Initialization	VSC Sensor Neutral Memorization	AFS ECU Initialization(Manual)	Vehicle Height Sensor Initialization(Manual)	Vehicle Height Sensor Initialization	Injector Compensation(Bosch)	ECB Utility	VIN	Learning Value Reset	Wireless Door Lock Diagnosis Mode	Engine Throttle Learning	Recognition Camera/Target Position Memory	Recognition Camera Axis Adjust	PCS Image Record Setting	PCS Image Information Clear	Control Mode	History Clear	Battery Status Info Update	Battery Status Info Update	Grill Shutter Control Mode Switching	Evaporative System Check	Brake Line Air Bleeding(For AHB-R)	iMT Installation Information Reset	Injector Maintenance Learning Value Reset	Switch Oil Maintenance Display	Switch Battery Type	ATF Thermal Degradation Estimate Reset	DPF Rejuvenate(PM)	Check the Cylinder Compression	Learning Value Confirmation	i-ART Learning Value Reset	Glow Control Unit Inspection	Upstream Turbine Pressure Learning Value Reset	Differential Pressure Learning Value Reset	NOx Storage Catalyst Learning Value Reset	Swirl Valve Learning Value Reset	Fuel PCV Compensation Value Reset	O2 Sensor Learning Value Reset	EGR Learning Value Reset	Supply Pump Learning Value Reset	Idle Speed Adjustment	DPF History Information Reset	DPF Rejuvenation Timing Reset	Air Flow Meter Learning Value Reset	A/T Code Registration	A/T Code Reset	Starter Start Count Set	Starter Start Count Clear	Customize
16PIN CONNECTOR	TCCS(Engine/AT)															V		V	V		V										V		V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V			
16PIN CONNECTOR	TCCS2(Engine/AT)																																																								
16PIN CONNECTOR	Transmission(ECT/SMT/MMT)	V									V																																															
16PIN CONNECTOR	Hybrid Vehicle		V																									V	V																														
16PIN CONNECTOR	Mild Hybrid Vehicle																																																									
16PIN CONNECTOR	Hybrid Vehicle Battery					V	V	V																																																		
16PIN CONNECTOR	ABS/VSC		V									V					V															V																										
16PIN CONNECTOR	ABS/VSC/ARS																																																									
16PIN CONNECTOR	Air Suspension/TEMS/AHC																																																									
16PIN CONNECTOR	Stabilizer																																																									
16PIN CONNECTOR	Electric Parking Brake																																																									
16PIN CONNECTOR	ARS(Active Rear Steer)																																																									
16PIN CONNECTOR	SRS Airbag																																																									
16PIN CONNECTOR	4WD(4 Wheel Drive)																																																									
16PIN CONNECTOR	EPS(Electric Power Steering)																																																									
16PIN CONNECTOR	Radar Cruise Control																																																									
16PIN CONNECTOR	Radar Cruise Control(HV)																																																									
16PIN CONNECTOR	Stop And Go																																																							V	V	
16PIN CONNECTOR	VGRS(Variable Gear Ratio Steering)																																																									
16PIN CONNECTOR	Immobiliser									V																																																
16PIN CONNECTOR	Precrash Safety System																																																									
16PIN CONNECTOR	IPA(Intelligent Parking Assist)																																																									
16PIN CONNECTOR	Combination meter																																																									V
16PIN CONNECTOR	EMS(Energy Management System)																																																									
16PIN CONNECTOR	Motor Generator																																																									
16PIN CONNECTOR	LKA(Lane Keeping Assist)																																																									
16PIN CONNECTOR	Active Stabilizer(Front)																																																									
16PIN CONNECTOR	Active Stabilizer(Rear)																																																									
16PIN CONNECTOR	Lane Departure Alert																					V	V	V	V	V	V																																
16PIN CONNECTOR	Front Recognition Camera																					V	V	V	V	V	V																																
16PIN CONNECTOR	Transmission Control																																																									
16PIN CONNECTOR	E-ACM(Electric Active Mount)																																																									
16PIN CONNECTOR	FCHV(Fuel Cell Hybrid Vehicle)		V																																																							
16PIN CONNECTOR	Vehicle Control																																																									
16PIN CONNECTOR	Grill Shutter																													V																													
16PIN CONNECTOR	Plug-in Control(HV)																																																									
16PIN CONNECTOR	KDSS(Kinetic Dynamic Suspension)																																																									
16PIN CONNECTOR	Tire Pressure Warning System				V																																																					
16PIN CONNECTOR	Charging Control																																																									
16PIN CONNECTOR	Starting Control																																																									
16PIN CONNECTOR	Gateway																																																									V
16PIN CONNECTOR	Body																																																									V
16PIN CONNECTOR	Body No.2																																																									V

Year	System	A/T Code Reset	Inspection Mode	ECU Information Sync	ID Registration	Onboard Equalizing Charge(beta)	SOC(STATUS OF CHARGING) SET(beta)	V80 Control SET(beta)	Zero Point Calibration	Key Code Reset(ECU Relearn)	Initialization	VSC Sensor Neutral Memorization	AFS ECU Initialization(Manual)	Vehicle Height Sensor Initialization(Manual)	Vehicle Height Sensor Initialization	Injector Compensation(Bosch)	ECB Utility	VIN	Learning Value Reset	Wireless Door Lock Diagnosis Mode	Engine Throttle Learning	Recognition Camera/Target Position Memory	Recognition Camera Axis Adjust	PCS Image Record Setting	PCS Image Information Clear	Control Mode	History Clear	Battery Status Info Update	Battery Status Info Update	Grill Shutter Control Mode Switching	Evaporative System Check	Brake Line Air Bleeding(For AHB-R)	iMT Installation Information Reset	Injector Maintenance Learning Value Reset	Switch Oil Maintenance Display	Switch Battery Type	ATF Thermal Degradation Estimate Reset	DPF Rejuvenate(PM)	Check the Cylinder Compression	Learning Value Confirmation	i-ART Learning Value Reset	Glow Control Unit Inspection	Upstream Turbine Pressure Learning Value Reset	Differential Pressure Learning Value Reset	NOx Storage Catalyst Learning Value Reset	Swirl Valve Learning Value Reset	Fuel PCV Compensation Value Reset	O2 Sensor Learning Value Reset	EGR Learning Value Reset	Supply Pump Learning Value Reset	Idle Speed Adjustment	DPF History Information Reset	DPF Rejuvenation Timing Reset	Air Flow Meter Learning Value Reset	A/T Code Registration	A/T Code Reset	Starter Start Count Set	Starter Start Count Clear	Customize
16PIN CONNECTOR	Body No.3																																																								V
16PIN CONNECTOR	Body No.4																																																								V
16PIN CONNECTOR	Body No.5																																																								
16PIN CONNECTOR	Hybrid Gateway																																																								
16PIN CONNECTOR	ECB Gateway																																																								
16PIN CONNECTOR	ECM Gateway																																																								
16PIN CONNECTOR	PM1 gateway																																																								
16PIN CONNECTOR	PM2 gateway																																																								
16PIN CONNECTOR	Accessory Gateway																																																								
16PIN CONNECTOR	Master Switch																																																								V
16PIN CONNECTOR	Combination Switch																																																								
16PIN CONNECTOR	Rear Console Switch																																																								
16PIN CONNECTOR	Air Conditioner																																																								V
16PIN CONNECTOR	Tilt And Telescopic																																																								
16PIN CONNECTOR	Driver Door(Mirror)																																																								V
16PIN CONNECTOR	Passenger Door																																																								
16PIN CONNECTOR	Rear Right Door																																																								V
16PIN CONNECTOR	Rear Left Door																																																								V
16PIN CONNECTOR	Back Door																																																								V
16PIN CONNECTOR	Driver Door Motor																																																								V
16PIN CONNECTOR	Passenger Door Motor																																																								V
16PIN CONNECTOR	Rear Right Door Motor																																																								V
16PIN CONNECTOR	Rear Left Door Motor																																																								V
16PIN CONNECTOR	Driver Seat																																																								V
16PIN CONNECTOR	Passenger Seat																																																								V
16PIN CONNECTOR	Rear Right Seat																																																								V
16PIN CONNECTOR	Rear Left Seat																																																								V
16PIN CONNECTOR	Driver Seat Switch																																																								V
16PIN CONNECTOR	Rear Right Seat Switch																																																								
16PIN CONNECTOR	Front Right Seat A/C																																																								V
16PIN CONNECTOR	Front Left Seat A/C																																																								V
16PIN CONNECTOR	Rear Right Seat A/C																																																								V
16PIN CONNECTOR	Rear Left Seat A/C																																																								V
16PIN CONNECTOR	Slide Roof																																																								V
16PIN CONNECTOR	Rain Sensor																																																								
16PIN CONNECTOR	Wiper																																																								V
16PIN CONNECTOR	Occupant Detection								V																																																
16PIN CONNECTOR	Night View																																																								
16PIN CONNECTOR	Steering Pad(Pad Switch)																																																								
16PIN CONNECTOR	Power Source Control																																																								
16PIN CONNECTOR	Electric Power Control																																																								
16PIN CONNECTOR	Entry And Start																				V																																				V
16PIN CONNECTOR	Theft Deterrent System																																																								V

Year	System	A/T Code Reset	Inspection Mode	ECU Information Sync	ID Registration	Onboard Equalizing Charge(beta)	SOC(STATUS OF CHARGING) SET(beta)	V80 Control SET(beta)	Zero Point Calibration	Key Code Reset(ECU Relearn)	Initialization	VSC Sensor Neutral Memorization	AFS ECU Initialization(Manual)	Vehicle Height Sensor Initialization(Manual)	Vehicle Height Sensor Initialization	Injector Compensation(Bosch)	ECB Utility	VIN	Learning Value Reset	Wireless Door Lock Diagnosis Mode	Engine Throttle Learning	Recognition Camera/Target Position Memory	Recognition Camera Axis Adjust	PCS Image Record Setting	PCS Image Information Clear	Control Mode	History Clear	Battery Status Info Update	Battery Status Info Update	Grill Shutter Control Mode Switching	Evaporative System Check	Brake Line Air Bleeding(For AHB-R)	iMT Installation Information Reset	Injector Maintenance Learning Value Reset	Switch Oil Maintenance Display	Switch Battery Type	ATF Thermal Degradation Estimate Reset	DPF Rejuvenate(PM)	Check the Cylinder Compression	Learning Value Confirmation	i-ART Learning Value Reset	Glow Control Unit Inspection	Upstream Turbine Pressure Learning Value Reset	Differential Pressure Learning Value Reset	NOx Storage Catalyst Learning Value Reset	Swirl Valve Learning Value Reset	Fuel PCV Compensation Value Reset	O2 Sensor Learning Value Reset	EGR Learning Value Reset	Supply Pump Learning Value Reset	Idle Speed Adjustment	DPF History Information Reset	DPF Rejuvenation Timing Reset	Air Flow Meter Learning Value Reset	A/T Code Registration	A/T Code Reset	Starter Start Count Set	Starter Start Count Clear	Customize
16PIN CONNECTOR	Clearance Sonar																																																										V
16PIN CONNECTOR	Retractable Hard Top																																																											V
16PIN CONNECTOR	Left Seat Mirror																																																											V
16PIN CONNECTOR	Right Seat Mirror																																																											V
16PIN CONNECTOR	AFS(Adaptive Front-Lighting System)			V									V	V	V																																													
16PIN CONNECTOR	WIL Gateway																																																											
16PIN CONNECTOR	Remote Security																																																											
16PIN CONNECTOR	Driver Seat Act Headrest																																																											
16PIN CONNECTOR	Help Net Gateway																																																											
16PIN CONNECTOR	Central Gateway										V																																																	
16PIN CONNECTOR	Precrash 2										V																																																	
16PIN CONNECTOR	Passenger Seat Act Headrest																																																											
16PIN CONNECTOR	Navigation System																																																											
16PIN CONNECTOR	Remote Engine Starter																																																											V
16PIN CONNECTOR	Panoramic View Monitor																																																											
16PIN CONNECTOR	Blind Spot Monitor Master																																																											
16PIN CONNECTOR	Blind Spot Monitor Slave																																																											
16PIN CONNECTOR	Active Sound Control																																																											
16PIN CONNECTOR	Multi Bus Gateway																																																											
16PIN CONNECTOR	Multi Bus Monitor1																																																											
16PIN CONNECTOR	Multi Bus Monitor2																																																											
16PIN CONNECTOR	Vehicle Proximity Notification																																																											
17PIN CONNECTOR	ALL(DTC)																																																											
17PIN CONNECTOR	ALL(DTC/CURR)																																																											
17PIN CONNECTOR	ECT(AT)																																																											
17PIN CONNECTOR	Vacuum ABS																																																											
17PIN CONNECTOR	Vacuum ABS/TRC/4WD																																																											
17PIN CONNECTOR	Hydraulic ABS/VSC/4WD																																																											
17PIN CONNECTOR	4WD																																																											
17PIN CONNECTOR	TEMS(PIEZO/SKYHOOK)																																																											
17PIN CONNECTOR	Air Suspension System																																																											
17PIN CONNECTOR	Active Suspension System																																																											
17PIN CONNECTOR	TRC(Traction Control System)																																																											
17PIN CONNECTOR	VSC(Vehicle Stability Control)																																																											
17PIN CONNECTOR	Cruise																																																											
17PIN CONNECTOR	Airbag																																																											
17PIN CONNECTOR	Side Airbag																																																											
17PIN CONNECTOR	Air Conditioner																																																											
17PIN CONNECTOR	4WS(4 Wheele Steering)																																																											
17PIN CONNECTOR	ETCS(Electronic Throttle Control System)																																																											

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	HV	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	BCM	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	ABS/ASR	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	HV	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	HV	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	Engine	V	V	V																																				
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	HSA/CFS	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	Engine	V	V	V																																				
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	Engine	V	V		V														V																					
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	AT	V	V		V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	Engine	V	V	V																																				
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	Engine	V	V		V														V																					
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	Engine	V	V	V	V																																			
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)		V		V														V	V																				
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	ABS/ASR	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	Engine	V	V		V														V																					
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	Engine	V	V		V														V																					
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	Engine	V	V		V														V																					
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	Engine	V	V		V														V																					

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	Engine	V	V	V	V																																			
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)		V		V														V	V																				
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	Engine	V	V	V	V																																			
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)		V		V														V	V																				
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	Engine	V	V	V																																				
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	Smoother	V	V		V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	Engine	V	V	V																																				
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	Engine	V	V	V	V																																			
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)		V		V														V	V																				
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	Engine	V	V	V	V												V																							
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	VIM(Vehicle Interface Module)		V		V														V	V																				
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	ABS/ASR	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	Engine	V	V	V	V												V																							
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	VIM(Vehicle Interface Module)		V		V														V	V																				
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	Engine	V	V	V	V																																			
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)		V		V														V	V																				
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	Engine	V	V	V	V												V																							
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	VIM(Vehicle Interface Module)		V		V														V	V																				
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	Engine	V	V	V	V																																			
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)		V		V														V	V																				
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	ABS/ASR	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	Engine	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	ABS/ASR	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	Engine	V	V	V	V						V		V	V	V	V		V	V	V					V															
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	Engine	V	V	V	V						V		V	V	V	V		V	V	V					V															
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	Engine	V	V	V	V									V	V	V			V	V																					
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	Engine	V	V	V	V									V	V	V			V	V																					
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	Engine	V	V	V	V						V		V	V	V	V		V	V	V					V															
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	Engine	V	V	V	V									V	V	V			V	V																				
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	Engine	V	V	V	V						V		V	V	V	V		V	V	V					V																
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	Engine	V	V	V	V									V	V	V			V	V																					
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	Engine	V	V	V	V						V		V	V	V	V		V	V	V					V																
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	Engine	V	V	V	V						V		V	V	V	V		V	V	V					V																
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	Engine	V	V	V	V									V	V	V			V	V																					
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	AT	V	V		V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	Engine	V	V	V	V						V		V	V	V	V		V	V	V					V															
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	Engine	V	V	V	V						V		V	V	V	V		V	V	V					V															
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	Engine	V	V	V	V									V	V	V			V	V																					
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	Engine	V	V	V	V						V		V	V	V	V		V	V	V					V															
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	Engine	V	V	V	V						V		V	V	V	V		V	V	V					V															
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	AT	V	V		V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	Engine	V	V	V	V									V	V	V			V	V																				
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	Engine	V	V	V	V									V	V	V			V	V																				
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	Engine	V	V	V	V						V		V	V	V	V		V	V	V					V																
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	Engine	V	V	V	V						V		V	V	V	V		V	V	V					V																
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	Engine	V	V	V	V									V	V	V			V	V																				
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	Engine	V	V	V	V						V	V	V	V	V	V		V				V		V	V															
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	HV	V			V																																			
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	AT	V	V		V																																			
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	Smoother	V	V		V																																			
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	Smoother	V			V																																			
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	HSA/CFS	V			V																																			
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	SRS Airbag	V	V		V																																			
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	BCM	V			V																																			
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	BCM(MIMAMORI)	V	V		V																																			
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	Immobiliser	V	V		V																																			
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																														
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	Engine	V	V	V	V																																			
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																														
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	ABS/ASR	V	V	V	V																																			
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	SRS Airbag	V			V																																			
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	BCM	V	V	V	V																					V				V	V	V	V	V	V	V	V	V	V	V

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	BCM	V	V	V	V																											V	V			V					
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	IPDM E/R	V	V	V	V																																				
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	Meter	V	V		V																																				
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	Engine	V	V	V	V																																				
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	ABS/ASR	V	V	V	V																																				
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	SRS Airbag	V			V																																				
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	BCM	V	V	V	V																					V				V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	BCM	V	V	V	V																											V	V			V					
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	IPDM E/R	V	V	V	V																																				
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	Meter	V	V		V																																				
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	Engine	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	ABS/ASR	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	SRS Airbag	V			V																																				
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	BCM	V	V	V	V																					V				V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	BCM	V	V	V	V																											V	V			V					
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	IPDM E/R	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	Meter	V	V		V																																				
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	Engine	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	ABS/ASR	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	SRS Airbag	V			V																																				
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	BCM	V	V	V	V																					V				V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	BCM	V	V	V	V																											V	V			V					
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	IPDM E/R	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	Meter	V	V		V																																				
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	Engine	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	ABS/ASR	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	SRS Airbag	V			V																																				
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	BCM	V	V	V	V																					V				V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	BCM	V	V	V	V																											V	V			V					
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	IPDM E/R	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	Meter	V	V		V																																				
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	Engine	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	ABS/ASR	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	SRS Airbag	V			V																																				

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	BCM	V	V	V	V																					V				V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	BCM	V	V	V	V																											V	V			V					
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	IPDM E/R	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	Meter	V	V		V																																				
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	Engine	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	ABS/ASR	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	SRS Airbag	V			V																																				
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	BCM	V	V	V	V																					V				V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	BCM	V	V	V	V																											V	V			V					
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	IPDM E/R	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	Meter	V	V		V																																				
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	Engine	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	Engine	V	V	V	V	V	V	V	V	V																															
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	ABS/ASR	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	SRS Airbag	V			V																																				
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	BCM	V	V	V	V																					V				V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	BCM	V	V	V	V																											V	V			V					
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	IPDM E/R	V	V	V	V																																				
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	Meter	V	V		V																																				
CONDOR(MEDIUM SIZE)	BDG-LK36C	J07E	'06.11 ~	Engine	V	V	V																																					
CONDOR(MEDIUM SIZE)	BDG-LK36C	J07E	'06.11 ~	ABS/ASR	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-LK36C	J07E	'06.11 ~	SRS Airbag	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-LK36E	J07E	'06.11 ~	Engine	V	V	V																																					
CONDOR(MEDIUM SIZE)	BDG-LK36E	J07E	'06.11 ~	ABS/ASR	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-LK36E	J07E	'06.11 ~	SRS Airbag	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-LK37C	J08E	'06.11 ~	Engine	V	V	V																																					
CONDOR(MEDIUM SIZE)	BDG-LK37C	J08E	'06.11 ~	ABS/ASR	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-LK37C	J08E	'06.11 ~	SRS Airbag	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-LK37E	J08E	'08.06 ~	Engine	V	V	V																																					
CONDOR(MEDIUM SIZE)	BDG-LK37E	J08E	'08.06 ~	ABS/ASR	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-LK37E	J08E	'08.06 ~	SRS Airbag	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-MK35C	J05D	'06.11 ~	Engine	V	V	V																																					
CONDOR(MEDIUM SIZE)	BDG-MK35C	J05D	'06.11 ~	ABS/ASR	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-MK35C	J05D	'06.11 ~	SRS Airbag	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-MK36C	J07E	'06.11 ~	Engine	V	V	V																																					
CONDOR(MEDIUM SIZE)	BDG-MK36C	J07E	'06.11 ~	ABS/ASR	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-MK36C	J07E	'06.11 ~	SRS Airbag	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-MK36D	J07E	'06.11 ~	Engine	V	V	V																																					
CONDOR(MEDIUM SIZE)	BDG-MK36D	J07E	'06.11 ~	ABS/ASR	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-MK36D	J07E	'06.11 ~	SRS Airbag	V			V																																				
CONDOR(MEDIUM SIZE)	BDG-MK37C	J07E	'06.11 ~	Engine	V	V	V																																					

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(MEDIUM SIZE)	BDG-MK37C	J07E	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	BDG-MK37C	J07E	'06.11 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	BDG-MK37D	J08E	'06.11 ~	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	BDG-MK37D	J08E	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	BDG-MK37D	J08E	'06.11 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	BDG-PK36C	J07E	'06.11 ~	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	BDG-PK36C	J07E	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	BDG-PK36C	J07E	'06.11 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	BDG-PK37C	J08E	'06.11 ~	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	BDG-PK37C	J08E	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	BDG-PK37C	J08E	'06.11 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	BDG-PK37D	J07E	'06.11 ~	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	BDG-PK37D	J07E	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	BDG-PK37D	J07E	'06.11 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	BDG-PW37C	J08E	'06.11 ~	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	BDG-PW37C	J08E	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	BDG-PW37C	J08E	'06.11 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	KK-LK25	FE6	'02.05 ~	Engine	V	V		V																																			
CONDOR(MEDIUM SIZE)	KK-LK25	FE6	'02.05 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	KK-LK26	MD92	'02.05 ~	Engine	V			V																																			
CONDOR(MEDIUM SIZE)	KK-LK26	MD92	'02.05 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	KK-MK21	FE6	'02.05 ~	Engine	V	V		V																																			
CONDOR(MEDIUM SIZE)	KK-MK21	FE6	'02.05 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	KK-MK25	FE6	'02.05 ~	Engine	V	V		V																																			
CONDOR(MEDIUM SIZE)	KK-MK25	FE6	'02.05 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	KK-MK26	MD92	'02.05 ~	Engine	V			V																																			
CONDOR(MEDIUM SIZE)	KK-MK26	MD92	'02.05 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	KL-PK25	FE6	'02.05 ~	Engine	V	V		V																																			
CONDOR(MEDIUM SIZE)	KL-PK25	FE6	'02.05 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	KL-PK26	MD92	'02.05 ~	Engine	V			V																																			
CONDOR(MEDIUM SIZE)	KL-PK26	MD92	'02.05 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	KL-PW25	FE6	'02.05 ~	Engine	V	V		V																																			
CONDOR(MEDIUM SIZE)	KL-PW25	FE6	'02.05 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	KS-PK36A	J07E	'06.11 ~	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	KS-PK36A	J07E	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	KS-PK36A	J07E	'06.11 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	KS-PK37A	J08E	'06.11 ~	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	KS-PK37A	J08E	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	KS-PK37A	J08E	'06.11 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	KS-PK37B	J08E	'06.11 ~	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	KS-PK37B	J08E	'06.11 ~	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	KS-PK37B	J08E	'06.11 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	KS-PW37A	J08E	'06.11 ~	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	KS-PW37A	J08E	'06.11 ~	ABS/ASR	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
CONDOR(MEDIUM SIZE)	KS-PW37A	J08E	'06.11 ~	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	PB-LK36A	J07E	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	PB-LK36A	J07E	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	PB-LK36A	J07E	'04.06 ~ '06.10	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	PB-LK37A	J08E	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	PB-LK37A	J08E	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	PB-LK37A	J08E	'04.06 ~ '06.10	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	PB-MK35A	J05D	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	PB-MK35A	J05D	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	PB-MK35A	J05D	'04.06 ~ '06.10	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	PB-MK36A	J07E	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	PB-MK36A	J07E	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	PB-MK36A	J07E	'04.06 ~ '06.10	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	PB-MK36B	J07E	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	PB-MK36B	J07E	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	PB-MK36B	J07E	'04.06 ~ '06.10	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	PB-MK37A	J08E	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	PB-MK37A	J08E	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	PB-MK37A	J08E	'04.06 ~ '06.10	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	PB-MK37B	J08E	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	PB-MK37B	J08E	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	PB-MK37B	J08E	'04.06 ~ '06.10	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	PB-PK36A	J07E	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	PB-PK36A	J07E	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	PB-PK36A	J07E	'04.06 ~ '06.10	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	PK-PK36A	J07E	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	PK-PK36A	J07E	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	PK-PK36A	J07E	'04.06 ~ '06.10	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	PK-PK37A	J08E	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	PK-PK37A	J08E	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	PK-PK37A	J08E	'04.06 ~ '06.10	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	PK-PK37B	J08E	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	PK-PK37B	J08E	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	PK-PK37B	J08E	'04.06 ~ '06.10	SRS Airbag	V			V																																			
CONDOR(MEDIUM SIZE)	PK-PW37A	J08E	'04.06 ~ '06.10	Engine	V	V	V																																				
CONDOR(MEDIUM SIZE)	PK-PW37A	J08E	'04.06 ~ '06.10	ABS/ASR	V			V																																			
CONDOR(MEDIUM SIZE)	PK-PW37A	J08E	'04.06 ~ '06.10	SRS Airbag	V			V																																			
BigThumb	KL-CD48	GE13	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CD48	GE13	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CD48	GE13	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CD53	RG8	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CD53	RG8	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CD53	RG8	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CD55	RH8	'02.02 ~	Engine	V	V		V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
BigThumb	KL-CD55	RH8	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CD55	RH8	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CG27	MD92	'02.02 ~	Engine	V			V																																			
BigThumb	KL-CG27	MD92	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CG27	MD92	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CG48	GE13	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CG48	GE13	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CG48	GE13	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CG55	RH8	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CG55	RH8	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CG55	RH8	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CK48	GE13	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CK48	GE13	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CK48	GE13	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CK53	RG8	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CK53	RG8	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CK53	RG8	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CK54	RF8	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CK54	RF8	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CK54	RF8	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CK55	RH8	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CK55	RH8	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CK55	RH8	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CV27	MD92	'02.02 ~	Engine	V			V																																			
BigThumb	KL-CV27	MD92	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CV27	MD92	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CV48	GE13	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CV48	GE13	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CV48	GE13	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CW48	GE13	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CW48	GE13	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CW48	GE13	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CW53	RG8	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CW53	RG8	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CW53	RG8	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CW54	RF8	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CW54	RF8	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CW54	RF8	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CW55	RH8	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CW55	RH8	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CW55	RH8	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CX27	MD92	'02.02 ~	Engine	V			V																																			
BigThumb	KL-CX27	MD92	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CX27	MD92	'02.02 ~	SRS Airbag	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
BigThumb	KL-CX48	GE13	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CX48	GE13	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CX48	GE13	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CX55	RH8	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CX55	RH8	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CX55	RH8	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	KL-CZ55	RH8	'02.02 ~	Engine	V	V		V																																			
BigThumb	KL-CZ55	RH8	'02.02 ~	ESCOT	V	V	V	V																																			
BigThumb	KL-CZ55	RH8	'02.02 ~	SRS Airbag	V			V																																			
BigThumb	GI-TC27	RH8	2002.02 ~	Engine	V	V		V																																			
BigThumb	GI-TC27	RH8	2002.02 ~	UDS	V	V	V	V																																			
BigThumb	GI-TC27	RH8	2002.02 ~	ESCOT	V	V	V	V																																			
BigThumb	GI-TC27	RH8	2002.02 ~	SRS Airbag	V			V																																			
BigThumb	GI-TC48	RH8	2002.02 ~	Engine	V	V		V																																			
BigThumb	GI-TC48	RH8	2002.02 ~	UDS	V	V	V	V																																			
BigThumb	GI-TC48	RH8	2002.02 ~	ESCOT	V	V	V	V																																			
BigThumb	GI-TC48	RH8	2002.02 ~	SRS Airbag	V			V																																			
BigThumb	GI-TC55	RH8	2002.02 ~	Engine	V	V		V																																			
BigThumb	GI-TC55	RH8	2002.02 ~	UDS	V	V	V	V																																			
BigThumb	GI-TC55	RH8	2002.02 ~	ESCOT	V	V	V	V																																			
BigThumb	GI-TC55	RH8	2002.02 ~	SRS Airbag	V			V																																			
QUON	ADG-CD2	MD92	'05.05 ~	Engine	V	V		V									V	V																									
QUON	ADG-CD2	MD92	'05.05 ~	UDS	V	V	V	V																																			
QUON	ADG-CD2	MD92	'05.05 ~	ESCOT	V	V	V	V																																			
QUON	ADG-CD2	MD92	'05.05 ~	SRS Airbag	V			V																																			
QUON	ADG-CD4	GE13	'04.11 ~	Engine	V	V		V									V	V																									
QUON	ADG-CD4	GE13	'04.11 ~	UDS	V	V	V	V																																			
QUON	ADG-CD4	GE13	'04.11 ~	ESCOT	V	V	V	V																																			
QUON	ADG-CD4	GE13	'04.11 ~	SRS Airbag	V			V																																			
QUON	ADG-CF4	GE13	'05.06 ~	Engine	V	V		V									V	V																									
QUON	ADG-CF4	GE13	'05.06 ~	UDS	V	V	V	V																																			
QUON	ADG-CF4	GE13	'05.06 ~	ESCOT	V	V	V	V																																			
QUON	ADG-CF4	GE13	'05.06 ~	SRS Airbag	V			V																																			
QUON	ADG-CG2	MD92	'05.05 ~	Engine	V	V		V									V	V																									
QUON	ADG-CG2	MD92	'05.05 ~	UDS	V	V	V	V																																			
QUON	ADG-CG2	MD92	'05.05 ~	ESCOT	V	V	V	V																																			
QUON	ADG-CG2	MD92	'05.05 ~	SRS Airbag	V			V																																			
QUON	ADG-CG4	GE13	'04.11 ~	Engine	V	V		V									V	V																									
QUON	ADG-CG4	GE13	'04.11 ~	UDS	V	V	V	V																																			
QUON	ADG-CG4	GE13	'04.11 ~	ESCOT	V	V	V	V																																			
QUON	ADG-CG4	GE13	'04.11 ~	SRS Airbag	V			V																																			
QUON	ADG-CK2	MD92	'05.05 ~	Engine	V	V		V									V	V																									
QUON	ADG-CK2	MD92	'05.05 ~	UDS	V	V	V	V																																			
QUON	ADG-CK2	MD92	'05.05 ~	ESCOT	V	V	V	V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
QUON	ADG-CK2	MD92	'05.05 ~	SRS Airbag	V			V																																			
QUON	ADG-CV2	MD92	'05.05 ~	Engine	V	V		V									V	V																									
QUON	ADG-CV2	MD92	'05.05 ~	UDS	V	V	V	V																																			
QUON	ADG-CV2	MD92	'05.05 ~	ESCOT	V	V	V	V																																			
QUON	ADG-CV2	MD92	'05.05 ~	SRS Airbag	V			V																																			
QUON	ADG-CV4	GE13	'05.06 ~	Engine	V	V		V									V	V																									
QUON	ADG-CV4	GE13	'05.06 ~	UDS	V	V	V	V																																			
QUON	ADG-CV4	GE13	'05.06 ~	ESCOT	V	V	V	V																																			
QUON	ADG-CV4	GE13	'05.06 ~	SRS Airbag	V			V																																			
QUON	ADG-CW2	MD92	'05.05 ~	Engine	V	V		V									V	V																									
QUON	ADG-CW2	MD92	'05.05 ~	UDS	V	V	V	V																																			
QUON	ADG-CW2	MD92	'05.05 ~	ESCOT	V	V	V	V																																			
QUON	ADG-CW2	MD92	'05.05 ~	SRS Airbag	V			V																																			
QUON	ADG-CW4	GE13	'05.05 ~	Engine	V	V		V									V	V																									
QUON	ADG-CW4	GE13	'05.05 ~	UDS	V	V	V	V																																			
QUON	ADG-CW4	GE13	'05.05 ~	ESCOT	V	V	V	V																																			
QUON	ADG-CW4	GE13	'05.05 ~	SRS Airbag	V			V																																			
QUON	ADG-CX2	MD92	'05.05 ~	Engine	V	V		V									V	V																									
QUON	ADG-CX2	MD92	'05.05 ~	UDS	V	V	V	V																																			
QUON	ADG-CX2	MD92	'05.05 ~	ESCOT	V	V	V	V																																			
QUON	ADG-CX2	MD92	'05.05 ~	SRS Airbag	V			V																																			
QUON	ADG-CX4	GE13	'05.06 ~	Engine	V	V		V									V	V																									
QUON	ADG-CX4	GE13	'05.06 ~	UDS	V	V	V	V																																			
QUON	ADG-CX4	GE13	'05.06 ~	ESCOT	V	V	V	V																																			
QUON	ADG-CX4	GE13	'05.06 ~	SRS Airbag	V			V																																			
QUON	ADG-CZ4	GE13	'05.06 ~	Engine	V	V		V									V	V																									
QUON	ADG-CZ4	GE13	'05.06 ~	UDS	V	V	V	V																																			
QUON	ADG-CZ4	GE13	'05.06 ~	ESCOT	V	V	V	V																																			
QUON	ADG-CZ4	GE13	'05.06 ~	SRS Airbag	V			V																																			
QUON	ADG-GK4	GE13	'05.06 ~	Engine	V	V		V									V	V																									
QUON	ADG-GK4	GE13	'05.06 ~	UDS	V	V	V	V																																			
QUON	ADG-GK4	GE13	'05.06 ~	ESCOT	V	V	V	V																																			
QUON	ADG-GK4	GE13	'05.06 ~	SRS Airbag	V			V																																			
QUON	ADG-GW4	GE13	'05.06 ~	Engine	V	V		V									V	V																									
QUON	ADG-GW4	GE13	'05.06 ~	UDS	V	V	V	V																																			
QUON	ADG-GW4	GE13	'05.06 ~	ESCOT	V	V	V	V																																			
QUON	ADG-GW4	GE13	'05.06 ~	SRS Airbag	V			V																																			
QUON	AKG-GK4	GE13	'06.06 ~	Engine	V	V		V									V	V																									
QUON	AKG-GK4	GE13	'06.06 ~	UDS	V	V	V	V																																			
QUON	AKG-GK4	GE13	'06.06 ~	ESCOT	V	V	V	V																																			
QUON	AKG-GK4	GE13	'06.06 ~	SRS Airbag	V			V																																			
QUON	PKG-GK4	GE13	'07.01 ~	Engine	V	V		V									V	V																									
QUON	PKG-GK4	GE13	'07.01 ~	UDS	V	V	V	V																																			
QUON	PKG-GK4	GE13	'07.01 ~	ESCOT	V	V	V	V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	DTC Analysis	Data Analysis	Actuation Test	ECU Information	Quick TAS Learning	ETC Learning Clear	Air Fuel Ratio Learning Value Clear	Ignition Timing Correction	Idle RPM Correction	DPD Forced Regeneration	DPD Slowly Forced Regeneration	DPD Regeneration Data Reset	Injector ID Code Check	Injector ID Code Resistration	ID Code Up/Down Load	Pump Learning Value Clear	MAF Compensation Up/Down Load	Engine Start Counter	Start Exchange Counter	EGR V/POS Learned Value Clear	MAF Compensation Data	Fuel Delivery Rate Data	Reset Fuel Pump Correction	MAF Compensation Service Mode	STANG SEN ADJUSTMENT	DECEL G SEN CALIBRATION	SIDE G SEN CALIBRATION	PRESS SEN CALIBRATION	RESET SETTING VALUE	SECURITY DOOR LOCK SET	DOOR LOCK-UNLOCK SET	ANTI-LOCK OUT SET	AUTO LOCK SET	SET REAR DEFOGGER -ENG INTCON	ROOM LAMP TIMER SET	SET I/L D-UNLOCK INTCON	ROOM LAMP ON TIME SET	ROOM LAMP OFF TIME SET	R LAMP TIMER LOGIC SET	ROOM LAMP ON AT LOCK
QUON	PKG-GK4	GE13	'07.01 ~	SRS Airbag	V			V																																			
QUON	PKG-CD4	GE13	'06.09 ~	Engine	V	V		V									V	V																									
QUON	PKG-CD4	GE13	'06.09 ~	UDS	V	V	V	V																																			
QUON	PKG-CD4	GE13	'06.09 ~	ESCOT	V	V	V	V																																			
QUON	PKG-CD4	GE13	'06.09 ~	SRS Airbag	V			V																																			
QUON	PKG-CG4	GE13	'06.09 ~	Engine	V	V		V									V	V																									
QUON	PKG-CG4	GE13	'06.09 ~	UDS	V	V	V	V																																			
QUON	PKG-CG4	GE13	'06.09 ~	ESCOT	V	V	V	V																																			
QUON	PKG-CG4	GE13	'06.09 ~	SRS Airbag	V			V																																			
QUON	PKG-CV4	GE13	'06.09 ~	Engine	V	V		V									V	V																									
QUON	PKG-CV4	GE13	'06.09 ~	UDS	V	V	V	V																																			
QUON	PKG-CV4	GE13	'06.09 ~	ESCOT	V	V	V	V																																			
QUON	PKG-CV4	GE13	'06.09 ~	SRS Airbag	V			V																																			
QUON	PKG-CW4	GE13	'06.09 ~	Engine	V	V		V									V	V																									
QUON	PKG-CW4	GE13	'06.09 ~	UDS	V	V	V	V																																			
QUON	PKG-CW4	GE13	'06.09 ~	ESCOT	V	V	V	V																																			
QUON	PKG-CW4	GE13	'06.09 ~	SRS Airbag	V			V																																			
QUON	PKG-CX4	GE13	'06.09 ~	Engine	V	V		V									V	V																									
QUON	PKG-CX4	GE13	'06.09 ~	UDS	V	V	V	V																																			
QUON	PKG-CX4	GE13	'06.09 ~	ESCOT	V	V	V	V																																			
QUON	PKG-CX4	GE13	'06.09 ~	SRS Airbag	V			V																																			
SPACE ARROW	ADG-RA273	MD92	'05.06 ~	Engine	V	V		V									V	V																									
SPACE ARROW	ADG-RA273	MD92	'05.06 ~	UDS	V	V	V	V																																			
SPACE RUNNER	PB-RM360	J07E	'05.01 ~	Engine	V	V	V																																				
SPACE RUNNER	PB-RM360	J07E	'05.01 ~	ABS/ASR	V			V																																			
SPACE RUNNER	PB-RM360	J07E	'05.01 ~	SRS Airbag	V			V																																			
SPACE RUNNER	PDG-RA273	MD92	'06.06 ~	Engine	V	V		V									V	V																									
SPACE RUNNER	PDG-RA273	MD92	'06.06 ~	UDS	V	V	V	V																																			
SPACE RUNNER	PKG-AP35	MD92	'07.10 ~	Engine	V	V		V									V	V																									
SPACE RUNNER	PKG-AP35	MD92	'07.10 ~	UDS	V	V	V	V																																			
SPACE RUNNER	PKG-RA274	MD92	'06.06 ~	Engine	V	V		V									V	V																									
SPACE RUNNER	PKG-RA274	MD92	'06.06 ~	UDS	V	V	V	V																																			
SPACE RUNNER	PK-JP360	J07E	'05.01 ~	Engine	V	V	V																																				
SPACE RUNNER	PK-JP360	J07E	'05.01 ~	ABS/ASR	V			V																																			
SPACE RUNNER	PK-JP360	J07E	'05.01 ~	SRS Airbag	V			V																																			
SPACE RUNNER	PK-RP360	J07E	'07.01 ~	Engine	V	V	V																																				
SPACE RUNNER	PK-RP360	J07E	'07.01 ~	ABS/ASR	V			V																																			
SPACE RUNNER	PK-RP360	J07E	'07.01 ~	SRS Airbag	V			V																																			

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	Engine																																								
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	AT																																								
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	BCM																																								
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	Engine																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	AT																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	BCM																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	HV																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	BCM																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	Engine																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	HV																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	AT																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	ABS/ASR																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	BCM																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	Engine																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	HV																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	AT																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	BCM																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	HV																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	BCM																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	HV																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	Engine																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	HSA/CFS																							V	V	V	V														

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	Engine																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	Engine																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	Engine																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	AT																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	Engine																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	AT																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Engine																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	Engine																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	AT																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	Engine																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	AT																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	Engine																																								
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	AT																																								
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	ABS/ASR																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	Engine																																								
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	AT																																								
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	Engine																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	AT																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	Engine																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	AT																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	Engine																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	AT																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	Engine																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	AT																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	Engine																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	AT																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	Engine																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	AT																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	Engine																																								
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	AT																																								
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	Engine																																								
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	AT																																								
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Engine																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	Smoother																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	Engine																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	Engine																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	Engine																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	AT																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	ABS/ASR																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	Engine																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	AT																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	Engine																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	AT																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	Engine																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	AT																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	ABS/ASR																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	BCM																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	Engine																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	AT																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	BCM																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	Engine																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	AT																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	BCM																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	Engine																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	AT																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	BCM																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	Engine																																								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	AT																																								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	ABS/ASR																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	BCM																																								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	Engine																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	AT																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	Engine																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	AT																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																								V	V	V	V													

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	Engine																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	AT																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																								V	V	V	V													
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	AT																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	Engine																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	AT																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	Engine																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	AT																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	Engine																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	AT																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	Engine																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	AT																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																							V	V	V	V														

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	HSA/CFS																							V	V	V	V														
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	BCM																																								
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	BCM(MIMAMORI)																																								
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	BCM	V	V	V	V	V	V	V	V	V	V							V	V	V	V	V	V	V																	

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	BCM	V							V	V	V	V	V	V	V	V	V		V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	BCM	V	V	V	V	V	V	V	V	V	V							V	V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	BCM	V							V	V	V	V	V	V	V	V	V		V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	BCM	V	V	V	V	V	V	V	V	V	V							V	V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	BCM	V							V	V	V	V	V	V	V	V	V		V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	BCM	V	V	V	V	V	V	V	V	V	V							V	V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	BCM	V							V	V	V	V	V	V	V	V	V		V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	BCM	V	V	V	V	V	V	V	V	V	V							V	V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	BCM	V							V	V	V	V	V	V	V	V	V		V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	SRS Airbag																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	BCM	V	V	V	V	V	V	V	V	V	V							V	V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	BCM	V							V	V	V	V	V	V	V	V	V		V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	BCM	V	V	V	V	V	V	V	V	V	V							V	V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	BCM	V							V	V	V	V	V	V	V	V	V		V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	BCM	V	V	V	V	V	V	V	V	V	V							V	V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	BCM	V							V	V	V	V	V	V	V	V	V		V	V	V	V	V	V																	
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	Meter																																								
CONDOR(MEDIUM SIZE)	BDG-LK36C	J07E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	BDG-LK36C	J07E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-LK36C	J07E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-LK36E	J07E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	BDG-LK36E	J07E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-LK36E	J07E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-LK37C	J08E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	BDG-LK37C	J08E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-LK37C	J08E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-LK37E	J08E	'08.06 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	BDG-LK37E	J08E	'08.06 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-LK37E	J08E	'08.06 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-MK35C	J05D	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	BDG-MK35C	J05D	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-MK35C	J05D	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-MK36C	J07E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	BDG-MK36C	J07E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-MK36C	J07E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-MK36D	J07E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	BDG-MK36D	J07E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-MK36D	J07E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-MK37C	J07E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V	V

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(MEDIUM SIZE)	BDG-MK37C	J07E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-MK37C	J07E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-MK37D	J08E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	BDG-MK37D	J08E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-MK37D	J08E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-PK36C	J07E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	BDG-PK36C	J07E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-PK36C	J07E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-PK37C	J08E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	BDG-PK37C	J08E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-PK37C	J08E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-PK37D	J07E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	BDG-PK37D	J07E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-PK37D	J07E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-PW37C	J08E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	BDG-PW37C	J08E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-PW37C	J08E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	KK-LK25	FE6	'02.05 ~	Engine																																								
CONDOR(MEDIUM SIZE)	KK-LK25	FE6	'02.05 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	KK-LK26	MD92	'02.05 ~	Engine																																								
CONDOR(MEDIUM SIZE)	KK-LK26	MD92	'02.05 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	KK-MK21	FE6	'02.05 ~	Engine																																								
CONDOR(MEDIUM SIZE)	KK-MK21	FE6	'02.05 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	KK-MK25	FE6	'02.05 ~	Engine																																								
CONDOR(MEDIUM SIZE)	KK-MK25	FE6	'02.05 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	KK-MK26	MD92	'02.05 ~	Engine																																								
CONDOR(MEDIUM SIZE)	KK-MK26	MD92	'02.05 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	KL-PK25	FE6	'02.05 ~	Engine																																								
CONDOR(MEDIUM SIZE)	KL-PK25	FE6	'02.05 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	KL-PK26	MD92	'02.05 ~	Engine																																								
CONDOR(MEDIUM SIZE)	KL-PK26	MD92	'02.05 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	KL-PW25	FE6	'02.05 ~	Engine																																								
CONDOR(MEDIUM SIZE)	KL-PW25	FE6	'02.05 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	KS-PK36A	J07E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	KS-PK36A	J07E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	KS-PK36A	J07E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	KS-PK37A	J08E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	KS-PK37A	J08E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	KS-PK37A	J08E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	KS-PK37B	J08E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	KS-PK37B	J08E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	KS-PK37B	J08E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	KS-PW37A	J08E	'06.11 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	KS-PW37A	J08E	'06.11 ~	ABS/ASR																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
CONDOR(MEDIUM SIZE)	KS-PW37A	J08E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	PB-LK36A	J07E	'04.06 ~ '06.10	Engine																												V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	PB-LK36A	J07E	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	PB-LK36A	J07E	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	PB-LK37A	J08E	'04.06 ~ '06.10	Engine																												V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	PB-LK37A	J08E	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	PB-LK37A	J08E	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	PB-MK35A	J05D	'04.06 ~ '06.10	Engine																												V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	PB-MK35A	J05D	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	PB-MK35A	J05D	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	PB-MK36A	J07E	'04.06 ~ '06.10	Engine																												V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	PB-MK36A	J07E	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	PB-MK36A	J07E	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	PB-MK36B	J07E	'04.06 ~ '06.10	Engine																												V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	PB-MK36B	J07E	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	PB-MK36B	J07E	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	PB-MK37A	J08E	'04.06 ~ '06.10	Engine																												V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	PB-MK37A	J08E	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	PB-MK37A	J08E	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	PB-MK37B	J08E	'04.06 ~ '06.10	Engine																												V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	PB-MK37B	J08E	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	PB-MK37B	J08E	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	PB-PK36A	J07E	'04.06 ~ '06.10	Engine																												V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	PB-PK36A	J07E	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	PB-PK36A	J07E	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	PK-PK36A	J07E	'04.06 ~ '06.10	Engine																												V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	PK-PK36A	J07E	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	PK-PK36A	J07E	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	PK-PK37A	J08E	'04.06 ~ '06.10	Engine																												V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	PK-PK37A	J08E	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	PK-PK37A	J08E	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	PK-PK37B	J08E	'04.06 ~ '06.10	Engine																												V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	PK-PK37B	J08E	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	PK-PK37B	J08E	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	PK-PW37A	J08E	'04.06 ~ '06.10	Engine																												V	V	V	V	V	V	V	V	V	V	V	V	V
CONDOR(MEDIUM SIZE)	PK-PW37A	J08E	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	PK-PW37A	J08E	'04.06 ~ '06.10	SRS Airbag																																								
BigThumb	KL-CD48	GE13	'02.02 ~	Engine																																								
BigThumb	KL-CD48	GE13	'02.02 ~	ESCOT																																								
BigThumb	KL-CD48	GE13	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CD53	RG8	'02.02 ~	Engine																																								
BigThumb	KL-CD53	RG8	'02.02 ~	ESCOT																																								
BigThumb	KL-CD53	RG8	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CD55	RH8	'02.02 ~	Engine																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
BigThumb	KL-CD55	RH8	'02.02 ~	ESCOT																																								
BigThumb	KL-CD55	RH8	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CG27	MD92	'02.02 ~	Engine																																								
BigThumb	KL-CG27	MD92	'02.02 ~	ESCOT																																								
BigThumb	KL-CG27	MD92	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CG48	GE13	'02.02 ~	Engine																																								
BigThumb	KL-CG48	GE13	'02.02 ~	ESCOT																																								
BigThumb	KL-CG48	GE13	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CG55	RH8	'02.02 ~	Engine																																								
BigThumb	KL-CG55	RH8	'02.02 ~	ESCOT																																								
BigThumb	KL-CG55	RH8	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CK48	GE13	'02.02 ~	Engine																																								
BigThumb	KL-CK48	GE13	'02.02 ~	ESCOT																																								
BigThumb	KL-CK48	GE13	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CK53	RG8	'02.02 ~	Engine																																								
BigThumb	KL-CK53	RG8	'02.02 ~	ESCOT																																								
BigThumb	KL-CK53	RG8	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CK54	RF8	'02.02 ~	Engine																																								
BigThumb	KL-CK54	RF8	'02.02 ~	ESCOT																																								
BigThumb	KL-CK54	RF8	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CK55	RH8	'02.02 ~	Engine																																								
BigThumb	KL-CK55	RH8	'02.02 ~	ESCOT																																								
BigThumb	KL-CK55	RH8	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CV27	MD92	'02.02 ~	Engine																																								
BigThumb	KL-CV27	MD92	'02.02 ~	ESCOT																																								
BigThumb	KL-CV27	MD92	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CV48	GE13	'02.02 ~	Engine																																								
BigThumb	KL-CV48	GE13	'02.02 ~	ESCOT																																								
BigThumb	KL-CV48	GE13	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CW48	GE13	'02.02 ~	Engine																																								
BigThumb	KL-CW48	GE13	'02.02 ~	ESCOT																																								
BigThumb	KL-CW48	GE13	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CW53	RG8	'02.02 ~	Engine																																								
BigThumb	KL-CW53	RG8	'02.02 ~	ESCOT																																								
BigThumb	KL-CW53	RG8	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CW54	RF8	'02.02 ~	Engine																																								
BigThumb	KL-CW54	RF8	'02.02 ~	ESCOT																																								
BigThumb	KL-CW54	RF8	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CW55	RH8	'02.02 ~	Engine																																								
BigThumb	KL-CW55	RH8	'02.02 ~	ESCOT																																								
BigThumb	KL-CW55	RH8	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CX27	MD92	'02.02 ~	Engine																																								
BigThumb	KL-CX27	MD92	'02.02 ~	ESCOT																																								
BigThumb	KL-CX27	MD92	'02.02 ~	SRS Airbag																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
BigThumb	KL-CX48	GE13	'02.02 ~	Engine																																								
BigThumb	KL-CX48	GE13	'02.02 ~	ESCOT																																								
BigThumb	KL-CX48	GE13	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CX55	RH8	'02.02 ~	Engine																																								
BigThumb	KL-CX55	RH8	'02.02 ~	ESCOT																																								
BigThumb	KL-CX55	RH8	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CZ55	RH8	'02.02 ~	Engine																																								
BigThumb	KL-CZ55	RH8	'02.02 ~	ESCOT																																								
BigThumb	KL-CZ55	RH8	'02.02 ~	SRS Airbag																																								
BigThumb	GI-TC27	RH8	2002.02 ~	Engine																																								
BigThumb	GI-TC27	RH8	2002.02 ~	UDS																																								
BigThumb	GI-TC27	RH8	2002.02 ~	ESCOT																																								
BigThumb	GI-TC27	RH8	2002.02 ~	SRS Airbag																																								
BigThumb	GI-TC48	RH8	2002.02 ~	Engine																																								
BigThumb	GI-TC48	RH8	2002.02 ~	UDS																																								
BigThumb	GI-TC48	RH8	2002.02 ~	ESCOT																																								
BigThumb	GI-TC48	RH8	2002.02 ~	SRS Airbag																																								
BigThumb	GI-TC55	RH8	2002.02 ~	Engine																																								
BigThumb	GI-TC55	RH8	2002.02 ~	UDS																																								
BigThumb	GI-TC55	RH8	2002.02 ~	ESCOT																																								
BigThumb	GI-TC55	RH8	2002.02 ~	SRS Airbag																																								
QUON	ADG-CD2	MD92	'05.05 ~	Engine																															V	V	V	V						
QUON	ADG-CD2	MD92	'05.05 ~	UDS																																								
QUON	ADG-CD2	MD92	'05.05 ~	ESCOT																																								
QUON	ADG-CD2	MD92	'05.05 ~	SRS Airbag																																								
QUON	ADG-CD4	GE13	'04.11 ~	Engine																															V	V		V						
QUON	ADG-CD4	GE13	'04.11 ~	UDS																																								
QUON	ADG-CD4	GE13	'04.11 ~	ESCOT																																								
QUON	ADG-CD4	GE13	'04.11 ~	SRS Airbag																																								
QUON	ADG-CF4	GE13	'05.06 ~	Engine																															V	V		V						
QUON	ADG-CF4	GE13	'05.06 ~	UDS																																								
QUON	ADG-CF4	GE13	'05.06 ~	ESCOT																																								
QUON	ADG-CF4	GE13	'05.06 ~	SRS Airbag																																								
QUON	ADG-CG2	MD92	'05.05 ~	Engine																															V	V	V	V						
QUON	ADG-CG2	MD92	'05.05 ~	UDS																																								
QUON	ADG-CG2	MD92	'05.05 ~	ESCOT																																								
QUON	ADG-CG2	MD92	'05.05 ~	SRS Airbag																																								
QUON	ADG-CG4	GE13	'04.11 ~	Engine																															V	V		V						
QUON	ADG-CG4	GE13	'04.11 ~	UDS																																								
QUON	ADG-CG4	GE13	'04.11 ~	ESCOT																																								
QUON	ADG-CG4	GE13	'04.11 ~	SRS Airbag																																								
QUON	ADG-CK2	MD92	'05.05 ~	Engine																															V	V	V	V						
QUON	ADG-CK2	MD92	'05.05 ~	UDS																																								
QUON	ADG-CK2	MD92	'05.05 ~	ESCOT																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
QUON	ADG-CK2	MD92	'05.05 ~	SRS Airbag																																								
QUON	ADG-CV2	MD92	'05.05 ~	Engine																															V	V	V	V						
QUON	ADG-CV2	MD92	'05.05 ~	UDS																																								
QUON	ADG-CV2	MD92	'05.05 ~	ESCOT																																								
QUON	ADG-CV2	MD92	'05.05 ~	SRS Airbag																																								
QUON	ADG-CV4	GE13	'05.06 ~	Engine																															V	V		V						
QUON	ADG-CV4	GE13	'05.06 ~	UDS																																								
QUON	ADG-CV4	GE13	'05.06 ~	ESCOT																																								
QUON	ADG-CV4	GE13	'05.06 ~	SRS Airbag																																								
QUON	ADG-CW2	MD92	'05.05 ~	Engine																															V	V	V	V						
QUON	ADG-CW2	MD92	'05.05 ~	UDS																																								
QUON	ADG-CW2	MD92	'05.05 ~	ESCOT																																								
QUON	ADG-CW2	MD92	'05.05 ~	SRS Airbag																																								
QUON	ADG-CW4	GE13	'05.05 ~	Engine																															V	V		V						
QUON	ADG-CW4	GE13	'05.05 ~	UDS																																								
QUON	ADG-CW4	GE13	'05.05 ~	ESCOT																																								
QUON	ADG-CW4	GE13	'05.05 ~	SRS Airbag																																								
QUON	ADG-CX2	MD92	'05.05 ~	Engine																															V	V	V	V						
QUON	ADG-CX2	MD92	'05.05 ~	UDS																																								
QUON	ADG-CX2	MD92	'05.05 ~	ESCOT																																								
QUON	ADG-CX2	MD92	'05.05 ~	SRS Airbag																																								
QUON	ADG-CX4	GE13	'05.06 ~	Engine																															V	V		V						
QUON	ADG-CX4	GE13	'05.06 ~	UDS																																								
QUON	ADG-CX4	GE13	'05.06 ~	ESCOT																																								
QUON	ADG-CX4	GE13	'05.06 ~	SRS Airbag																																								
QUON	ADG-CZ4	GE13	'05.06 ~	Engine																															V	V		V						
QUON	ADG-CZ4	GE13	'05.06 ~	UDS																																								
QUON	ADG-CZ4	GE13	'05.06 ~	ESCOT																																								
QUON	ADG-CZ4	GE13	'05.06 ~	SRS Airbag																																								
QUON	ADG-GK4	GE13	'05.06 ~	Engine																															V	V		V						
QUON	ADG-GK4	GE13	'05.06 ~	UDS																																								
QUON	ADG-GK4	GE13	'05.06 ~	ESCOT																																								
QUON	ADG-GK4	GE13	'05.06 ~	SRS Airbag																																								
QUON	ADG-GW4	GE13	'05.06 ~	Engine																															V	V		V						
QUON	ADG-GW4	GE13	'05.06 ~	UDS																																								
QUON	ADG-GW4	GE13	'05.06 ~	ESCOT																																								
QUON	ADG-GW4	GE13	'05.06 ~	SRS Airbag																																								
QUON	AKG-GK4	GE13	'06.06 ~	Engine																															V	V		V						
QUON	AKG-GK4	GE13	'06.06 ~	UDS																																								
QUON	AKG-GK4	GE13	'06.06 ~	ESCOT																																								
QUON	AKG-GK4	GE13	'06.06 ~	SRS Airbag																																								
QUON	PKG-GK4	GE13	'07.01 ~	Engine																															V	V		V						
QUON	PKG-GK4	GE13	'07.01 ~	UDS																																								
QUON	PKG-GK4	GE13	'07.01 ~	ESCOT																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	REMO CONT ID ERASUR	BATTERY SAVER SET	CUSTOM A/LIGHT SETTING	HEAD LIGHT TIMER	ILL DELAY SET	RR WIP RVRS SET	WIPER SPEED SETTING	HAZARD LAMP SET	ROOM LAMP BAT SAV SET	SECURITY ALARM SET	Security Alarm Trigger	Retention Power Supply Setting	Automatic Lock Setting	Head Lamp Automatic Light Setting	Head Lamp Battery Saver Setting	Illumination Delay Setting	THEFT ALM TRG	REMO CONT ID REGIST	REMO CONT ID CONFIR	PANIC ALARM SET	TRUNK OPEN SET	MULTI ANSWER BACK SET	PW DOWN SET	Gearshift, Select stroke learning	Clutch free clutch torque position learning1	Clutch free clutch torque position learning2	New clutch disc clutch position learning	DPR Status	Reset All DPR Status	Manual Regeneration	DPR Differential Pressure Check	Suction Air Volume Check	EGR Check	VNT Check	Fuel Leak Check	Supply Pump Specification Learning	Check Turbocharger	Drive Accelerator Sensor Adjust	Maximum Cruise Control Speed Setting	Maximum Vehicle Speed Setting
QUON	PKG-GK4	GE13	'07.01 ~	SRS Airbag																																								
QUON	PKG-CD4	GE13	'06.09 ~	Engine																															V	V		V						
QUON	PKG-CD4	GE13	'06.09 ~	UDS																																								
QUON	PKG-CD4	GE13	'06.09 ~	ESCOT																																								
QUON	PKG-CD4	GE13	'06.09 ~	SRS Airbag																																								
QUON	PKG-CG4	GE13	'06.09 ~	Engine																															V	V		V						
QUON	PKG-CG4	GE13	'06.09 ~	UDS																																								
QUON	PKG-CG4	GE13	'06.09 ~	ESCOT																																								
QUON	PKG-CG4	GE13	'06.09 ~	SRS Airbag																																								
QUON	PKG-CV4	GE13	'06.09 ~	Engine																															V	V		V						
QUON	PKG-CV4	GE13	'06.09 ~	UDS																																								
QUON	PKG-CV4	GE13	'06.09 ~	ESCOT																																								
QUON	PKG-CV4	GE13	'06.09 ~	SRS Airbag																																								
QUON	PKG-CW4	GE13	'06.09 ~	Engine																															V	V		V						
QUON	PKG-CW4	GE13	'06.09 ~	UDS																																								
QUON	PKG-CW4	GE13	'06.09 ~	ESCOT																																								
QUON	PKG-CW4	GE13	'06.09 ~	SRS Airbag																																								
QUON	PKG-CX4	GE13	'06.09 ~	Engine																															V	V		V						
QUON	PKG-CX4	GE13	'06.09 ~	UDS																																								
QUON	PKG-CX4	GE13	'06.09 ~	ESCOT																																								
QUON	PKG-CX4	GE13	'06.09 ~	SRS Airbag																																								
SPACE ARROW	ADG-RA273	MD92	'05.06 ~	Engine																															V	V	V	V						
SPACE ARROW	ADG-RA273	MD92	'05.06 ~	UDS																																								
SPACE RUNNER	PB-RM360	J07E	'05.01 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V	V
SPACE RUNNER	PB-RM360	J07E	'05.01 ~	ABS/ASR																																								
SPACE RUNNER	PB-RM360	J07E	'05.01 ~	SRS Airbag																																								
SPACE RUNNER	PDG-RA273	MD92	'06.06 ~	Engine																															V	V	V	V						
SPACE RUNNER	PDG-RA273	MD92	'06.06 ~	UDS																																								
SPACE RUNNER	PKG-AP35	MD92	'07.10 ~	Engine																															V	V	V	V						
SPACE RUNNER	PKG-AP35	MD92	'07.10 ~	UDS																																								
SPACE RUNNER	PKG-RA274	MD92	'06.06 ~	Engine																															V	V	V	V						
SPACE RUNNER	PKG-RA274	MD92	'06.06 ~	UDS																																								
SPACE RUNNER	PK-JP360	J07E	'05.01 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V	V
SPACE RUNNER	PK-JP360	J07E	'05.01 ~	ABS/ASR																																								
SPACE RUNNER	PK-JP360	J07E	'05.01 ~	SRS Airbag																																								
SPACE RUNNER	PK-RP360	J07E	'07.01 ~	Engine																											V	V	V	V	V	V	V	V	V	V	V	V	V	V
SPACE RUNNER	PK-RP360	J07E	'07.01 ~	ABS/ASR																																								
SPACE RUNNER	PK-RP360	J07E	'07.01 ~	SRS Airbag																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	Engine																													V	V	V	V								
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	AT																																								
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	AFG-BKR82	4HV1(CNG)	'05.04 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	Engine																													V	V	V	V								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	AT																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	AFG-BPR82	4HV1(CNG)	'05.04 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BDG-BJR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BDG-BKR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	HV																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BDG-BKS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BDG-BLR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BDG-BMR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BDG-BMS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BDG-BNR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BDG-BPR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BDG-BPS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	Engine																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	HV																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	AT																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	ABS/ASR																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BJG-BMR85	4JJ1-TC	'09.01 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	Engine																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	HV																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	AT																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BJG-BPR85	4JJ1-TC	'09.01 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BKG-BHR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BKG-BHS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	HV																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BKG-BJR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BKG-BJS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BKG-BKR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BKG-BLR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BKG-BLS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BKG-BMR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BKG-BNR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	HV																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BKG-BNS85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	Engine																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	HV																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	AT																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	Smoother																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	BKG-BPR85	4JJ1-TC	'06.11 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	HSA/CFS																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	Engine																																V	V	V						
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KG-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	HSA/CFS																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	Engine																																V	V	V						
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	HSA/CFS																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	Engine																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	AT																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	HSA/CFS																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2	'04.06 ~ '06.10	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	Engine																																V	V	V						
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BHS69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	Engine																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	AT																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	HSA/CFS																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1	'99.01 ~ '02.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	Engine																																V	V	V						
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	AT																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR66	4HF1(CNG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	HSA/CFS																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Engine																															V	V	V							
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	Engine																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	AT																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	HSA/CFS																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1	'99.01 ~ '03.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	Engine																															V	V	V							
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	AT																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR71	4HG1(LPG)	'02.04 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	Engine																																								
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	AT																																								
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	ABS/ASR																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	HSA/CFS																																									
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BKR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	Engine																																									
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	AT																																									
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	Smoother																																									
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	ABS/ASR																																									
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	HSA/CFS																																									
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BKS66	4HF1	'99.01 ~ '02.05	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	Engine																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	AT																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	Smoother																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	ABS/ASR																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	HSA/CFS																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1	'99.01 ~ '03.05	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	Engine																																V	V	V							
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	AT																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	Smoother																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	ABS/ASR																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	HSA/CFS																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BKS71	4HG1(LPG)	'02.04 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	Engine																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	AT																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	Smoother																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	ABS/ASR																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	HSA/CFS																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1	'99.01 ~ '02.05	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	Engine																																V	V	V							
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	AT																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	Smoother																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	ABS/ASR																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	HSA/CFS																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BPR66	4HF1(CNG)	'02.04 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	Engine																																									

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	AT																																									
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	Smoother																																									
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	ABS/ASR																																									
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	HSA/CFS																																									
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BPR71	4HG1	'99.01 ~ '03.05	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	Engine																																V	V	V							
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	AT																																									
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	Smoother																																									
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	ABS/ASR																																									
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	HSA/CFS																																									
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BPR71	4HG1(LPG)	'02.04 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	Engine																																									
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)																																									
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	AT																																									
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	Smoother																																									
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	ABS/ASR																																									
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	HSA/CFS																																									
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BPR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	Engine																																									
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)																																									
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	AT																																									
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	Smoother																																									
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	ABS/ASR																																									
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	HSA/CFS																																									
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BPS72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Engine																																V	V	V							
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	AT																																									
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	Smoother																																									
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	ABS/ASR																																									
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	HSA/CFS																																									
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	KK-BKR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	Engine																																									
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	AT																																									
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	HSA/CFS																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	Engine																																V	V	V						
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHR69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	HSA/CFS																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	Engine																																V	V	V						
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	AT																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	Smoother																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BHS69	4JG2(LPG)	'04.01 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	Engine																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	AT																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	HSA/CFS																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BKR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	ABS/ASR																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	HSA/CFS																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BKR81	4HL1	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	HSA/CFS																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BKS81	4HL1	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	Engine																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	AT																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	HSA/CFS																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BPR72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	Engine																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	AT																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	Smoother																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	HSA/CFS																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BPR81	4HL1	'02.06 ~ '04.05	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	Engine																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	VIM(Vehicle Interface Module)																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	AT																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	Smoother																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	ABS/ASR																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	HSA/CFS																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	KR-BPS72	4HJ1	'02.06 ~ '03.04	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	Engine																												V	V	V	V									
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	AT																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	ABS/ASR																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	NFG-BJR82	4HV1(CNG)	'07.07 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	Engine																													V	V	V	V								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	AT																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	NFG-BKR82	4HV1(CNG)	'07.07 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	Engine																													V	V	V	V								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	AT																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	NFG-BLR82	4HV1(CNG)	'07.07 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	Engine																													V	V	V	V								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	AT																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	HSA/CFS																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	BCM																V	V	V	V																					
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)															V																									
CONDOR(SMALL SIZE)	NFG-BMR82	4HV1(CNG)	'07.07 ~	Immobiliser																																								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	Engine																													V	V	V	V								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	AT																																								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																										
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	Smoother																																								
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	ABS/ASR																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	HSA/CFS																																									
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	BCM																V	V	V	V																						
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	BCM(MIMAMORI)															V																										
CONDOR(SMALL SIZE)	NFG-BPR82	4HV1(CNG)	'07.07 ~	Immobiliser																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	Engine																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	AT																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	Smoother																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	AT																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	Engine																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	AT																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	Smoother																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	ABS/ASR																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	HSA/CFS																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	AT																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PA-BPR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	AT																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																																									

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	AT																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BHR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	AT																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	AT																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BHS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	Engine																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	AT																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	Smoother																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	AT																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	AT																																									

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BKR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	Engine																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	AT																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	Smoother																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	AT																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	AT																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BKS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	Engine																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	AT																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	Smoother																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	AT																																									

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	Engine																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	AT																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	Smoother																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	AT																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPR81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	Engine																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	AT																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	Smoother																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'04.06 ~ '05.04	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	AT																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	HSA/CFS																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-NA	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	Engine																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	AT																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	Smoother																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	ABS/ASR																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	HSA/CFS																																									

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PB-BPS81	4HL1-TC	'05.05 ~ '06.10	SRS Airbag																																									
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	Engine																																									
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	HV																																									
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	AT																																									
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	Smoother																																									
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	ABS/ASR																																									
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	HSA/CFS																																									
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	BCM																V	V	V	V																						
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	BCM(MIMAMORI)															V																										
CONDOR(SMALL SIZE)	PDG-BKR85	4JJ1-TC	'06.11 ~	Immobiliser																																									
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	Engine																																									
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	HV																																									
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	AT																																									
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	Smoother																																									
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	ABS/ASR																																									
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	HSA/CFS																																									
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	BCM																V	V	V	V																						
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	BCM(MIMAMORI)															V																										
CONDOR(SMALL SIZE)	PDG-BPR75	4HK1-TC	'06.11 ~	Immobiliser																																									
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	Engine																																									
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	HV																																									
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	AT																																									
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	Smoother			V	V	V	V	V	V	V	V	V	V	V	V																											
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	Smoother																																									
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	ABS/ASR																																									
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	HSA/CFS																																									
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	BCM																V	V	V	V																						
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	BCM(MIMAMORI)															V																										
CONDOR(SMALL SIZE)	PKG-BPR75	4HK1-TC	'06.11 ~	Immobiliser																																									
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	Engine																																									
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	Engine																				V	V	V	V	V	V	V	V	V													
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	Engine																																									
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	ABS/ASR																																									
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	SRS Airbag																																									
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	BCM																																									

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	CBF-NSQ1F24	QR20DE	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	Engine																				V	V	V	V	V	V	V	V	V												
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	CBF-NSQ2F24	QR20DE	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	Engine																				V	V	V	V	V	V	V	V	V												
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	PDG-NSZ1F24	QR20DE	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	Engine																				V	V	V	V	V	V	V	V	V												
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	PDG-NSZ2F24	QR20DE	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	Engine																				V	V	V	V	V	V	V	V	V												
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	PDG-NSZ4F24	QR20DE	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	Engine																				V	V	V	V	V	V	V	V	V												
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	SRS Airbag																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	PDG-NSZ5F24	QR20DE	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	Engine																			V	V	V	V	V	V	V	V	V													
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	PDG-NTZ2F24	ZD30DDTi	'07.06 ~	Meter																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	Engine																			V	V	V	V	V	V	V	V	V													
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	Engine																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	ABS/ASR																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	SRS Airbag																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	BCM																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	IPDM E/R																																								
CONDOR(SMALL SIZE)	PDG-NTZ3F24	ZD30DDTi	'07.06 ~	Meter																																								
CONDOR(MEDIUM SIZE)	BDG-LK36C	J07E	'06.11 ~	Engine																																								
CONDOR(MEDIUM SIZE)	BDG-LK36C	J07E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-LK36C	J07E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-LK36E	J07E	'06.11 ~	Engine																																								
CONDOR(MEDIUM SIZE)	BDG-LK36E	J07E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-LK36E	J07E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-LK37C	J08E	'06.11 ~	Engine																																								
CONDOR(MEDIUM SIZE)	BDG-LK37C	J08E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-LK37C	J08E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-LK37E	J08E	'08.06 ~	Engine																																								
CONDOR(MEDIUM SIZE)	BDG-LK37E	J08E	'08.06 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-LK37E	J08E	'08.06 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-MK35C	J05D	'06.11 ~	Engine																																								
CONDOR(MEDIUM SIZE)	BDG-MK35C	J05D	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-MK35C	J05D	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-MK36C	J07E	'06.11 ~	Engine																																								
CONDOR(MEDIUM SIZE)	BDG-MK36C	J07E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-MK36C	J07E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-MK36D	J07E	'06.11 ~	Engine																																								
CONDOR(MEDIUM SIZE)	BDG-MK36D	J07E	'06.11 ~	ABS/ASR																																								
CONDOR(MEDIUM SIZE)	BDG-MK36D	J07E	'06.11 ~	SRS Airbag																																								
CONDOR(MEDIUM SIZE)	BDG-MK37C	J07E	'06.11 ~	Engine																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(MEDIUM SIZE)	BDG-MK37C	J07E	'06.11 ~	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	BDG-MK37C	J07E	'06.11 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	BDG-MK37D	J08E	'06.11 ~	Engine																																									
CONDOR(MEDIUM SIZE)	BDG-MK37D	J08E	'06.11 ~	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	BDG-MK37D	J08E	'06.11 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	BDG-PK36C	J07E	'06.11 ~	Engine																																									
CONDOR(MEDIUM SIZE)	BDG-PK36C	J07E	'06.11 ~	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	BDG-PK36C	J07E	'06.11 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	BDG-PK37C	J08E	'06.11 ~	Engine																																									
CONDOR(MEDIUM SIZE)	BDG-PK37C	J08E	'06.11 ~	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	BDG-PK37C	J08E	'06.11 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	BDG-PK37D	J07E	'06.11 ~	Engine																																									
CONDOR(MEDIUM SIZE)	BDG-PK37D	J07E	'06.11 ~	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	BDG-PK37D	J07E	'06.11 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	BDG-PW37C	J08E	'06.11 ~	Engine																																									
CONDOR(MEDIUM SIZE)	BDG-PW37C	J08E	'06.11 ~	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	BDG-PW37C	J08E	'06.11 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	KK-LK25	FE6	'02.05 ~	Engine																																									
CONDOR(MEDIUM SIZE)	KK-LK25	FE6	'02.05 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	KK-LK26	MD92	'02.05 ~	Engine																																									
CONDOR(MEDIUM SIZE)	KK-LK26	MD92	'02.05 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	KK-MK21	FE6	'02.05 ~	Engine																																									
CONDOR(MEDIUM SIZE)	KK-MK21	FE6	'02.05 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	KK-MK25	FE6	'02.05 ~	Engine																																									
CONDOR(MEDIUM SIZE)	KK-MK25	FE6	'02.05 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	KK-MK26	MD92	'02.05 ~	Engine																																									
CONDOR(MEDIUM SIZE)	KK-MK26	MD92	'02.05 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	KL-PK25	FE6	'02.05 ~	Engine																																									
CONDOR(MEDIUM SIZE)	KL-PK25	FE6	'02.05 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	KL-PK26	MD92	'02.05 ~	Engine																																									
CONDOR(MEDIUM SIZE)	KL-PK26	MD92	'02.05 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	KL-PW25	FE6	'02.05 ~	Engine																																									
CONDOR(MEDIUM SIZE)	KL-PW25	FE6	'02.05 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	KS-PK36A	J07E	'06.11 ~	Engine																																									
CONDOR(MEDIUM SIZE)	KS-PK36A	J07E	'06.11 ~	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	KS-PK36A	J07E	'06.11 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	KS-PK37A	J08E	'06.11 ~	Engine																																									
CONDOR(MEDIUM SIZE)	KS-PK37A	J08E	'06.11 ~	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	KS-PK37A	J08E	'06.11 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	KS-PK37B	J08E	'06.11 ~	Engine																																									
CONDOR(MEDIUM SIZE)	KS-PK37B	J08E	'06.11 ~	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	KS-PK37B	J08E	'06.11 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	KS-PW37A	J08E	'06.11 ~	Engine																																									
CONDOR(MEDIUM SIZE)	KS-PW37A	J08E	'06.11 ~	ABS/ASR																																									

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
CONDOR(MEDIUM SIZE)	KS-PW37A	J08E	'06.11 ~	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	PB-LK36A	J07E	'04.06 ~ '06.10	Engine																																									
CONDOR(MEDIUM SIZE)	PB-LK36A	J07E	'04.06 ~ '06.10	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	PB-LK36A	J07E	'04.06 ~ '06.10	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	PB-LK37A	J08E	'04.06 ~ '06.10	Engine																																									
CONDOR(MEDIUM SIZE)	PB-LK37A	J08E	'04.06 ~ '06.10	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	PB-LK37A	J08E	'04.06 ~ '06.10	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	PB-MK35A	J05D	'04.06 ~ '06.10	Engine																																									
CONDOR(MEDIUM SIZE)	PB-MK35A	J05D	'04.06 ~ '06.10	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	PB-MK35A	J05D	'04.06 ~ '06.10	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	PB-MK36A	J07E	'04.06 ~ '06.10	Engine																																									
CONDOR(MEDIUM SIZE)	PB-MK36A	J07E	'04.06 ~ '06.10	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	PB-MK36A	J07E	'04.06 ~ '06.10	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	PB-MK36B	J07E	'04.06 ~ '06.10	Engine																																									
CONDOR(MEDIUM SIZE)	PB-MK36B	J07E	'04.06 ~ '06.10	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	PB-MK36B	J07E	'04.06 ~ '06.10	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	PB-MK37A	J08E	'04.06 ~ '06.10	Engine																																									
CONDOR(MEDIUM SIZE)	PB-MK37A	J08E	'04.06 ~ '06.10	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	PB-MK37A	J08E	'04.06 ~ '06.10	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	PB-MK37B	J08E	'04.06 ~ '06.10	Engine																																									
CONDOR(MEDIUM SIZE)	PB-MK37B	J08E	'04.06 ~ '06.10	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	PB-MK37B	J08E	'04.06 ~ '06.10	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	PB-PK36A	J07E	'04.06 ~ '06.10	Engine																																									
CONDOR(MEDIUM SIZE)	PB-PK36A	J07E	'04.06 ~ '06.10	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	PB-PK36A	J07E	'04.06 ~ '06.10	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	PK-PK36A	J07E	'04.06 ~ '06.10	Engine																																									
CONDOR(MEDIUM SIZE)	PK-PK36A	J07E	'04.06 ~ '06.10	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	PK-PK36A	J07E	'04.06 ~ '06.10	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	PK-PK37A	J08E	'04.06 ~ '06.10	Engine																																									
CONDOR(MEDIUM SIZE)	PK-PK37A	J08E	'04.06 ~ '06.10	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	PK-PK37A	J08E	'04.06 ~ '06.10	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	PK-PK37B	J08E	'04.06 ~ '06.10	Engine																																									
CONDOR(MEDIUM SIZE)	PK-PK37B	J08E	'04.06 ~ '06.10	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	PK-PK37B	J08E	'04.06 ~ '06.10	SRS Airbag																																									
CONDOR(MEDIUM SIZE)	PK-PW37A	J08E	'04.06 ~ '06.10	Engine																																									
CONDOR(MEDIUM SIZE)	PK-PW37A	J08E	'04.06 ~ '06.10	ABS/ASR																																									
CONDOR(MEDIUM SIZE)	PK-PW37A	J08E	'04.06 ~ '06.10	SRS Airbag																																									
BigThumb	KL-CD48	GE13	'02.02 ~	Engine																																									
BigThumb	KL-CD48	GE13	'02.02 ~	ESCOT																																									
BigThumb	KL-CD48	GE13	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CD53	RG8	'02.02 ~	Engine																																									
BigThumb	KL-CD53	RG8	'02.02 ~	ESCOT																																									
BigThumb	KL-CD53	RG8	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CD55	RH8	'02.02 ~	Engine																																									

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
BigThumb	KL-CD55	RH8	'02.02 ~	ESCOT																																									
BigThumb	KL-CD55	RH8	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CG27	MD92	'02.02 ~	Engine																																									
BigThumb	KL-CG27	MD92	'02.02 ~	ESCOT																																									
BigThumb	KL-CG27	MD92	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CG48	GE13	'02.02 ~	Engine																																									
BigThumb	KL-CG48	GE13	'02.02 ~	ESCOT																																									
BigThumb	KL-CG48	GE13	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CG55	RH8	'02.02 ~	Engine																																									
BigThumb	KL-CG55	RH8	'02.02 ~	ESCOT																																									
BigThumb	KL-CG55	RH8	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CK48	GE13	'02.02 ~	Engine																																									
BigThumb	KL-CK48	GE13	'02.02 ~	ESCOT																																									
BigThumb	KL-CK48	GE13	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CK53	RG8	'02.02 ~	Engine																																									
BigThumb	KL-CK53	RG8	'02.02 ~	ESCOT																																									
BigThumb	KL-CK53	RG8	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CK54	RF8	'02.02 ~	Engine																																									
BigThumb	KL-CK54	RF8	'02.02 ~	ESCOT																																									
BigThumb	KL-CK54	RF8	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CK55	RH8	'02.02 ~	Engine																																									
BigThumb	KL-CK55	RH8	'02.02 ~	ESCOT																																									
BigThumb	KL-CK55	RH8	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CV27	MD92	'02.02 ~	Engine																																									
BigThumb	KL-CV27	MD92	'02.02 ~	ESCOT																																									
BigThumb	KL-CV27	MD92	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CV48	GE13	'02.02 ~	Engine																																									
BigThumb	KL-CV48	GE13	'02.02 ~	ESCOT																																									
BigThumb	KL-CV48	GE13	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CW48	GE13	'02.02 ~	Engine																																									
BigThumb	KL-CW48	GE13	'02.02 ~	ESCOT																																									
BigThumb	KL-CW48	GE13	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CW53	RG8	'02.02 ~	Engine																																									
BigThumb	KL-CW53	RG8	'02.02 ~	ESCOT																																									
BigThumb	KL-CW53	RG8	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CW54	RF8	'02.02 ~	Engine																																									
BigThumb	KL-CW54	RF8	'02.02 ~	ESCOT																																									
BigThumb	KL-CW54	RF8	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CW55	RH8	'02.02 ~	Engine																																									
BigThumb	KL-CW55	RH8	'02.02 ~	ESCOT																																									
BigThumb	KL-CW55	RH8	'02.02 ~	SRS Airbag																																									
BigThumb	KL-CX27	MD92	'02.02 ~	Engine																																									
BigThumb	KL-CX27	MD92	'02.02 ~	ESCOT																																									
BigThumb	KL-CX27	MD92	'02.02 ~	SRS Airbag																																									

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
BigThumb	KL-CX48	GE13	'02.02 ~	Engine																																								
BigThumb	KL-CX48	GE13	'02.02 ~	ESCOT																																								
BigThumb	KL-CX48	GE13	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CX55	RH8	'02.02 ~	Engine																																								
BigThumb	KL-CX55	RH8	'02.02 ~	ESCOT																																								
BigThumb	KL-CX55	RH8	'02.02 ~	SRS Airbag																																								
BigThumb	KL-CZ55	RH8	'02.02 ~	Engine																																								
BigThumb	KL-CZ55	RH8	'02.02 ~	ESCOT																																								
BigThumb	KL-CZ55	RH8	'02.02 ~	SRS Airbag																																								
BigThumb	GI-TC27	RH8	2002.02 ~	Engine																																								
BigThumb	GI-TC27	RH8	2002.02 ~	UDS																																						V	V
BigThumb	GI-TC27	RH8	2002.02 ~	ESCOT																																								
BigThumb	GI-TC27	RH8	2002.02 ~	SRS Airbag																																								
BigThumb	GI-TC48	RH8	2002.02 ~	Engine																																								
BigThumb	GI-TC48	RH8	2002.02 ~	UDS																																						V	V
BigThumb	GI-TC48	RH8	2002.02 ~	ESCOT																																								
BigThumb	GI-TC48	RH8	2002.02 ~	SRS Airbag																																								
BigThumb	GI-TC55	RH8	2002.02 ~	Engine																																								
BigThumb	GI-TC55	RH8	2002.02 ~	UDS																																						V	V
BigThumb	GI-TC55	RH8	2002.02 ~	ESCOT																																								
BigThumb	GI-TC55	RH8	2002.02 ~	SRS Airbag																																								
QUON	ADG-CD2	MD92	'05.05 ~	Engine	V	V																																	V	V			
QUON	ADG-CD2	MD92	'05.05 ~	UDS																																						V	V
QUON	ADG-CD2	MD92	'05.05 ~	ESCOT																																								
QUON	ADG-CD2	MD92	'05.05 ~	SRS Airbag																																								
QUON	ADG-CD4	GE13	'04.11 ~	Engine	V	V																																	V	V	V		
QUON	ADG-CD4	GE13	'04.11 ~	UDS																																						V	V
QUON	ADG-CD4	GE13	'04.11 ~	ESCOT																																								
QUON	ADG-CD4	GE13	'04.11 ~	SRS Airbag																																								
QUON	ADG-CF4	GE13	'05.06 ~	Engine	V	V																																	V	V	V		
QUON	ADG-CF4	GE13	'05.06 ~	UDS																																						V	V
QUON	ADG-CF4	GE13	'05.06 ~	ESCOT																																								
QUON	ADG-CF4	GE13	'05.06 ~	SRS Airbag																																								
QUON	ADG-CG2	MD92	'05.05 ~	Engine	V	V																																	V	V			
QUON	ADG-CG2	MD92	'05.05 ~	UDS																																						V	V
QUON	ADG-CG2	MD92	'05.05 ~	ESCOT																																								
QUON	ADG-CG2	MD92	'05.05 ~	SRS Airbag																																								
QUON	ADG-CG4	GE13	'04.11 ~	Engine	V	V																																	V	V	V		
QUON	ADG-CG4	GE13	'04.11 ~	UDS																																						V	V
QUON	ADG-CG4	GE13	'04.11 ~	ESCOT																																								
QUON	ADG-CG4	GE13	'04.11 ~	SRS Airbag																																								
QUON	ADG-CK2	MD92	'05.05 ~	Engine	V	V																																	V	V			
QUON	ADG-CK2	MD92	'05.05 ~	UDS																																						V	V
QUON	ADG-CK2	MD92	'05.05 ~	ESCOT																																								

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
QUON	ADG-CK2	MD92	'05.05 ~	SRS Airbag																																								
QUON	ADG-CV2	MD92	'05.05 ~	Engine	V	V																																	V	V			
QUON	ADG-CV2	MD92	'05.05 ~	UDS																																						V	V
QUON	ADG-CV2	MD92	'05.05 ~	ESCOT																																							
QUON	ADG-CV2	MD92	'05.05 ~	SRS Airbag																																							
QUON	ADG-CV4	GE13	'05.06 ~	Engine	V	V																																	V	V	V		
QUON	ADG-CV4	GE13	'05.06 ~	UDS																																						V	V
QUON	ADG-CV4	GE13	'05.06 ~	ESCOT																																							
QUON	ADG-CV4	GE13	'05.06 ~	SRS Airbag																																							
QUON	ADG-CW2	MD92	'05.05 ~	Engine	V	V																																	V	V			
QUON	ADG-CW2	MD92	'05.05 ~	UDS																																						V	V
QUON	ADG-CW2	MD92	'05.05 ~	ESCOT																																							
QUON	ADG-CW2	MD92	'05.05 ~	SRS Airbag																																							
QUON	ADG-CW4	GE13	'05.05 ~	Engine	V	V																																	V	V	V		
QUON	ADG-CW4	GE13	'05.05 ~	UDS																																						V	V
QUON	ADG-CW4	GE13	'05.05 ~	ESCOT																																							
QUON	ADG-CW4	GE13	'05.05 ~	SRS Airbag																																							
QUON	ADG-CX2	MD92	'05.05 ~	Engine	V	V																																	V	V			
QUON	ADG-CX2	MD92	'05.05 ~	UDS																																						V	V
QUON	ADG-CX2	MD92	'05.05 ~	ESCOT																																							
QUON	ADG-CX2	MD92	'05.05 ~	SRS Airbag																																							
QUON	ADG-CX4	GE13	'05.06 ~	Engine	V	V																																	V	V	V		
QUON	ADG-CX4	GE13	'05.06 ~	UDS																																						V	V
QUON	ADG-CX4	GE13	'05.06 ~	ESCOT																																							
QUON	ADG-CX4	GE13	'05.06 ~	SRS Airbag																																							
QUON	ADG-CZ4	GE13	'05.06 ~	Engine	V	V																																	V	V	V		
QUON	ADG-CZ4	GE13	'05.06 ~	UDS																																						V	V
QUON	ADG-CZ4	GE13	'05.06 ~	ESCOT																																							
QUON	ADG-CZ4	GE13	'05.06 ~	SRS Airbag																																							
QUON	ADG-GK4	GE13	'05.06 ~	Engine	V	V																																	V	V	V		
QUON	ADG-GK4	GE13	'05.06 ~	UDS																																						V	V
QUON	ADG-GK4	GE13	'05.06 ~	ESCOT																																							
QUON	ADG-GK4	GE13	'05.06 ~	SRS Airbag																																							
QUON	ADG-GW4	GE13	'05.06 ~	Engine	V	V																																	V	V	V		
QUON	ADG-GW4	GE13	'05.06 ~	UDS																																						V	V
QUON	ADG-GW4	GE13	'05.06 ~	ESCOT																																							
QUON	ADG-GW4	GE13	'05.06 ~	SRS Airbag																																							
QUON	AKG-GK4	GE13	'06.06 ~	Engine	V	V																																	V	V	V		
QUON	AKG-GK4	GE13	'06.06 ~	UDS																																						V	V
QUON	AKG-GK4	GE13	'06.06 ~	ESCOT																																							
QUON	AKG-GK4	GE13	'06.06 ~	SRS Airbag																																							
QUON	PKG-GK4	GE13	'07.01 ~	Engine	V	V																																	V	V	V		
QUON	PKG-GK4	GE13	'07.01 ~	UDS																																						V	V
QUON	PKG-GK4	GE13	'07.01 ~	ESCOT																																							

Vehicle	Chassis Type	Engine	YEAR	SYSTEM	Running Accel Sensor Adjust	PTO Accel Sensor Adjust	Smoother-Ex Initial Learning	Manual Half-Clutch Learning	Transmission Gear Select / Shift Position Learning	Half-Clutch Position Adjust Function	Speed Meter Drive Gear Learning	Vehicle Type Programming	PTO Request Engine RPM	Speed Meter Gear Programming	Tire Size Programming	Tire Correction Ratio Program	Longitudinal Deceleration Rate Rewriting	ABS installation Status Programming	MIMAMORI All Data Clear	RKE Registration	RKE Registration Clear	Hour Meter Infomation Clear	Fuel Data Display Clear	Service Regeneration	Enter Injector Calibration Data	EGR/V Learn Clear	TP Position Learn Clear	DIF EX PRE Learn Clear	DPF Data Clear	A/F Sensor Learn Clear	Injector Learning Value Clear	Mixture Raito Learning Value Clear	Injection Control α Learned Value Clear	A/F Threshold Clear	Idling Throttle Learned Value Clear	Full Closed Throttle Learned Value Clear	Idle Speed Control Learned Value Clear	O2 Sensor Threshold Clear	Idling Feedback Duty Average Value Clear	Fuel Injection Stop Test	Each Relay Check	Electric Fan Clutch	Commissioning	Dosing Valve Check
QUON	PKG-GK4	GE13	'07.01 ~	SRS Airbag																																								
QUON	PKG-CD4	GE13	'06.09 ~	Engine	V	V																																	V	V	V		
QUON	PKG-CD4	GE13	'06.09 ~	UDS																																						V	V
QUON	PKG-CD4	GE13	'06.09 ~	ESCOT																																							
QUON	PKG-CD4	GE13	'06.09 ~	SRS Airbag																																							
QUON	PKG-CG4	GE13	'06.09 ~	Engine	V	V																																	V	V	V		
QUON	PKG-CG4	GE13	'06.09 ~	UDS																																						V	V
QUON	PKG-CG4	GE13	'06.09 ~	ESCOT																																							
QUON	PKG-CG4	GE13	'06.09 ~	SRS Airbag																																							
QUON	PKG-CV4	GE13	'06.09 ~	Engine	V	V																																	V	V	V		
QUON	PKG-CV4	GE13	'06.09 ~	UDS																																						V	V
QUON	PKG-CV4	GE13	'06.09 ~	ESCOT																																							
QUON	PKG-CV4	GE13	'06.09 ~	SRS Airbag																																							
QUON	PKG-CW4	GE13	'06.09 ~	Engine	V	V																																	V	V	V		
QUON	PKG-CW4	GE13	'06.09 ~	UDS																																						V	V
QUON	PKG-CW4	GE13	'06.09 ~	ESCOT																																							
QUON	PKG-CW4	GE13	'06.09 ~	SRS Airbag																																							
QUON	PKG-CX4	GE13	'06.09 ~	Engine	V	V																																	V	V	V		
QUON	PKG-CX4	GE13	'06.09 ~	UDS																																						V	V
QUON	PKG-CX4	GE13	'06.09 ~	ESCOT																																							
QUON	PKG-CX4	GE13	'06.09 ~	SRS Airbag																																							
SPACE ARROW	ADG-RA273	MD92	'05.06 ~	Engine	V	V																																	V	V			
SPACE ARROW	ADG-RA273	MD92	'05.06 ~	UDS																																						V	V
SPACE RUNNER	PB-RM360	J07E	'05.01 ~	Engine																																							
SPACE RUNNER	PB-RM360	J07E	'05.01 ~	ABS/ASR																																							
SPACE RUNNER	PB-RM360	J07E	'05.01 ~	SRS Airbag																																							
SPACE RUNNER	PDG-RA273	MD92	'06.06 ~	Engine	V	V																																	V	V			
SPACE RUNNER	PDG-RA273	MD92	'06.06 ~	UDS																																						V	V
SPACE RUNNER	PKG-AP35	MD92	'07.10 ~	Engine	V	V																																	V	V			
SPACE RUNNER	PKG-AP35	MD92	'07.10 ~	UDS																																						V	V
SPACE RUNNER	PKG-RA274	MD92	'06.06 ~	Engine	V	V																																	V	V			
SPACE RUNNER	PKG-RA274	MD92	'06.06 ~	UDS																																						V	V
SPACE RUNNER	PK-JP360	J07E	'05.01 ~	Engine																																							
SPACE RUNNER	PK-JP360	J07E	'05.01 ~	ABS/ASR																																							
SPACE RUNNER	PK-JP360	J07E	'05.01 ~	SRS Airbag																																							
SPACE RUNNER	PK-RP360	J07E	'07.01 ~	Engine																																							
SPACE RUNNER	PK-RP360	J07E	'07.01 ~	ABS/ASR																																							
SPACE RUNNER	PK-RP360	J07E	'07.01 ~	SRS Airbag																																							

Vehicle	Kind	System1	System2	System3	DTC Analysis	Erase	Data Analysis	Actuation Test	ECU Information Display	Special Function
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	January 5.1	V	V	V	V	V	Reset On Ignition
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	January 7.2	V	V	V	V	V	Reset On Ignition
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	General Motor ISFI-2S	V	V	V	V		
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	Bosch M1.5.4	V	V	V	V	V	Reset On Ignition
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	Bosch M1.5.4 +	V	V	V	V	V	Reset On Ignition
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	Bosch M1.5.4(New)	V	V	V	V	V	Reset On Ignition
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	Bosch MP7.0 EURO 2	V	V	V	V	V	Reset On IgnitionReset Initialization
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	Bosch M7.9.7 EURO 2	V	V	V	V	V	Reset On IgnitionReset Initialization
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	Bosch M7.9.7 EURO 3	V	V	V	V	V	Reset On IgnitionReset Initialization
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	Bosch M7.9.7 EURO 4	V	V	V	V	V	Reset On IgnitionReset Initialization
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	M74	V	V	V	V	V	Reset On IgnitionReset Initialization
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	Bosch ME17.9.7	V	V	V	V	V	Reset On IgnitionReset Initialization
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	M74K	V	V	V	V	V	Reset On IgnitionReset InitializationEngine Start Parameter
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ENGINE	M73 EURO 3	V	V	V	V	V	Reset On IgnitionReset Initialization
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ABS	Bosch ABS 8	V	V	V		V	
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	ABS	Bosch ABS 8.1	V	V	V		V	
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	AIRBAG	VAZ-1118	V	V	V	V	V	
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	AIRBAG	VAZ-2170	V	V	V	V	V	
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	CLIMATE CONTROL	Conditioner	V	V	V	V	V	
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	CLIMATE CONTROL	Conditioner VIS	V	V	V	V	V	
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	CLIMATE CONTROL	Panasonic	V	V	V	V	V	
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	STEERING	VAZ-1118	V	V	V		V	Reset On IgnitionReset Initialization
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	STEERING	VAZ-2170	V	V	V		V	Reset On IgnitionReset Initialization
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	STEERING	MANDO Co	V	V	V		V	
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	BODY ELECTONIC	VAZ-1118	V	V	V	V	V	
VAZ/GAZ/UAZ	VAZ(LADA)	16 Pin Connector	IMMOBILIZER	Ver 6			V	V		
VAZ/GAZ/UAZ	GAZ	16 Pin Connector	ENGINE	MIKAS 5.47	V	V	V	V		
VAZ/GAZ/UAZ	GAZ	16 Pin Connector	ENGINE	MIKAS 7.1	V	V	V	V		
VAZ/GAZ/UAZ	GAZ	16 Pin Connector	ENGINE	MIKAS 11 EURO 2	V	V	V	V	V	Reset On IgnitionReset Initialization
VAZ/GAZ/UAZ	GAZ	16 Pin Connector	ENGINE	MIKAS 10.3	V	V	V	V	V	Idle SpeedCO Trimming XXCO Trimming
VAZ/GAZ/UAZ	GAZ	16 Pin Connector	ENGINE	MIKAS 11.3	V	V	V	V	V	Idle SpeedCO Trimming XXCO Trimming
VAZ/GAZ/UAZ	UAZ	16 Pin Connector	ENGINE	MIKAS 5.47	V	V	V	V		
VAZ/GAZ/UAZ	UAZ	16 Pin Connector	ENGINE	MIKAS 7.1	V	V	V	V		
VAZ/GAZ/UAZ	UAZ	16 Pin Connector	ENGINE	MIKAS 11 EURO 2	V	V	V	V	V	Reset On IgnitionReset Initialization
VAZ/GAZ/UAZ	UAZ	16 Pin Connector	ENGINE	MIKAS 10.3	V	V	V	V	V	Idle SpeedCO Trimming XXCO Trimming
VAZ/GAZ/UAZ	UAZ	16 Pin Connector	ENGINE	MIKAS 11.3	V	V	V	V	V	Idle SpeedCO Trimming XXCO Trimming

Vehicle	System		DTC Analysis	Data Analysis	Actuation Test	Identification	Special Function
Samand	Engine	SL96	V	V	V	V	
		S2000	V	V	V	V	Initialising the autoadaptives
		S2000 (LC)	V	V	V	V	Initialising the autoadaptives
		Petrol SIEMENS (Normal & CNG)	V	V	V	V	Adaptive value reseting
		Bosch ME7.4.4	V	V	V	V	
		Gas SIEMENS (CNG)	V	V	V	V	-
		Bifuel BOSCH ME7.4.9NG Immo	V	V	V	V	Cruise Control Activation Setting of CNG tanks
		Petrol BOSCH ME7.4.9PT Immo	V	V	V	V	-
		OMVL	V	V	V	V	-
		Bosch MP7.3 (Sarir)	V	V	V	V	Initialising the autoadaptives
		Bifuel SIEMENS	V	V	V	V	Adaptive value reseting
		Petrol SIEMENS EF7	V	V	V	V	-
		Bifuel SIEMENS EF7	V	V	V	V	-
		SIEMENS Micro Hybrid	V	V	V	V	-
		EF7 TC	V	V	V	V	-
	ABS	MANDO MGH25 / MGH60	V	V	V	V	Bleeding
		TEVES MK20	V	V	V	V	-
		TEVES MK70	V	V	V	-	Bleeding
		BOSCH	V	V	V	V	Bleeding
		Mobis	V	V	V	V	Bleeding
	AirBag	HAE 2.5	V	-	-	V	-
		SRS	V	V	-	V	-
		EIMEN	V	-	-	V	-
		Crouse	V	-	-	V	-
	Multiplex	CCN	V	V	V	V	-
		FN	V	V	V	V	-
		DDN	V	V	V	V	-
		PDN	V	V	V	V	-
		ICN	-	-	V	V	-
	Key Learning	SIEMENS	-	-	-	-	Immobilizer
		VALEO	-	-	-	-	Immobilizer
	ECU Reset		V	-	-	-	ECU Reset
TURPIAL (PRIDE)	ENGINE	SIEMENS	V	V	V	V	Reset Adaptation Value
		VALEO	V	V	V	V	-
		S2000	V	V	V	V	Initialising the autoadaptives
		BOSCH	V	V	V	V	-
		CNG SIEMENS	V	V	V	V	-
	ABS	MANDO ABS	V	V	V	V	-
	IMMOBILIZER	VALEO	V	V	-	-	Immobilizer
		SIEMENS	V	V	-	V	Immo,ICU Change

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
C Series(COUPES)	Maintenance		BCM(Brake control module) Service function						V	V	V	V	V	V																					
C Series(COUPES)	Maintenance		PBM(Parking brake module) Service function			V									V	V	V	V	V																
C Series(COUPES)	Maintenance		Service Reminder Reset		V			V												V	V														
C Series(COUPES)	Maintenance		Technical Information																			V	V												
C Series(COUPES)	C30	2012	System Search																																
C Series(COUPES)	C30	2012	ECM(Engine Control Module)		V			V																											
C Series(COUPES)	C30	2012	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
C Series(COUPES)	C30	2012	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
C Series(COUPES)	C30	2012	SAS(Steering Angle Sensor module)		V	V		V																											
C Series(COUPES)	C30	2012	BCM(Brake Control Module)		V	V	V	V																											
C Series(COUPES)	C30	2012	SRS(Supplemental Restraint System)		V	V		V																											
C Series(COUPES)	C30	2012	DIM(Driver Information Module)		V	V	V	V													V							V	V	V	V				
C Series(COUPES)	C30	2012	CEM(Central Electrical Module)		V	V	V	V																								V	V		
C Series(COUPES)	C30	2012	PDM(Passenger door module)		V	V	V	V																											
C Series(COUPES)	C30	2012	DDM(Driver door module)		V	V	V	V																											
C Series(COUPES)	C30	2012	EPS(Electrical power steering module)		V	V		V																											
C Series(COUPES)	C30	2012	HCM(Headlamp control module)		V	V		V																											
C Series(COUPES)	C30	2011	System Search																																
C Series(COUPES)	C30	2011	ECM(Engine Control Module)		V			V																											
C Series(COUPES)	C30	2011	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
C Series(COUPES)	C30	2011	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
C Series(COUPES)	C30	2011	SAS(Steering Angle Sensor module)		V	V		V																											
C Series(COUPES)	C30	2011	BCM(Brake Control Module)		V	V	V	V																											
C Series(COUPES)	C30	2011	SRS(Supplemental Restraint System)		V	V		V																											
C Series(COUPES)	C30	2011	DIM(Driver Information Module)		V	V	V	V													V							V	V	V	V				
C Series(COUPES)	C30	2011	CEM(Central Electrical Module)		V	V	V	V																								V	V		
C Series(COUPES)	C30	2011	PDM(Passenger door module)		V	V	V	V																											
C Series(COUPES)	C30	2011	DDM(Driver door module)		V	V	V	V																											
C Series(COUPES)	C30	2011	EPS(Electrical power steering module)		V	V		V																											
C Series(COUPES)	C30	2011	HCM(Headlamp control module)		V	V		V																											
C Series(COUPES)	C30	2010	System Search																																
C Series(COUPES)	C30	2010	ECM(Engine Control Module)		V			V																											
C Series(COUPES)	C30	2010	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
C Series(COUPES)	C30	2010	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
C Series(COUPES)	C30	2010	ABS(Anti-Lock Brake System)		V			V																											
C Series(COUPES)	C30	2010	SAS(Steering Angle Sensor module)		V	V		V																											
C Series(COUPES)	C30	2010	BCM(Brake Control Module)		V	V	V	V																											
C Series(COUPES)	C30	2010	SRS(Supplemental Restraint System)		V	V		V																											
C Series(COUPES)	C30	2010	DIM(Driver Information Module)		V	V	V	V													V							V	V	V	V				
C Series(COUPES)	C30	2010	CEM(Central Electrical Module)		V	V	V	V																								V	V		
C Series(COUPES)	C30	2010	PDM(Passenger door module)		V	V	V	V																											
C Series(COUPES)	C30	2010	DDM(Driver door module)		V	V	V	V																											
C Series(COUPES)	C30	2010	PSM(Power Seat Module)		V			V																											
C Series(COUPES)	C30	2010	CCM(Climate Control Module)		V			V																											
C Series(COUPES)	C30	2010	EPS(Electrical power steering module)		V	V		V																											
C Series(COUPES)	C30	2010	SWM(Steering Wheel Module)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
C Series(COUPES)	C30	2010	HCM(Headlamp control module)		V	V		V																											
C Series(COUPES)	C30	2009	System Search																																
C Series(COUPES)	C30	2009	ECM(Engine Control Module)		V			V																											
C Series(COUPES)	C30	2009	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
C Series(COUPES)	C30	2009	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
C Series(COUPES)	C30	2009	ABS(Anti-Lock Brake System)		V			V																											
C Series(COUPES)	C30	2009	SAS(Steering Angle Sensor module)		V	V		V																											
C Series(COUPES)	C30	2009	BCM(Brake Control Module)		V	V	V	V																											
C Series(COUPES)	C30	2009	SRS(Supplemental Restraint System)		V	V		V																											
C Series(COUPES)	C30	2009	DIM(Driver Information Module)		V	V	V	V													V							V	V	V	V				
C Series(COUPES)	C30	2009	CEM(Central Electrical Module)		V	V	V	V																								V	V		
C Series(COUPES)	C30	2009	PDM(Passenger door module)		V	V	V	V																											
C Series(COUPES)	C30	2009	DDM(Driver door module)		V	V	V	V																											
C Series(COUPES)	C30	2009	PSM(Power Seat Module)		V			V																											
C Series(COUPES)	C30	2009	CCM(Climate Control Module)		V			V																											
C Series(COUPES)	C30	2009	EPS(Electrical power steering module)		V	V		V																											
C Series(COUPES)	C30	2009	SWM(Steering Wheel Module)		V			V																											
C Series(COUPES)	C30	2009	HCM(Headlamp control module)		V	V		V																											
C Series(COUPES)	C30	2008	System Search																																
C Series(COUPES)	C30	2008	ECM(Engine Control Module)		V			V																										V	V
C Series(COUPES)	C30	2008	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V											
C Series(COUPES)	C30	2008	TCM(Transmission Control Module)	AW55-50 - 51 SN	V	V	V	V																V											
C Series(COUPES)	C30	2008	ABS(Anti-Lock Brake System)		V			V																											
C Series(COUPES)	C30	2008	SRS(Supplemental Restraint System)		V	V		V																											
C Series(COUPES)	C30	2008	DIM(Driver Information Module)		V	V	V	V													V							V	V	V	V				
C Series(COUPES)	C30	2008	PAM(Parking Assistance Module)		V	V																													
C Series(COUPES)	C30	2008	CEM(Central Electrical Module)		V			V																											
C Series(COUPES)	C30	2008	ICM(Infotainment Control Module)		V	V		V																											
C Series(COUPES)	C30	2008	PDM(Passenger Door Module)		V	V	V	V																											
C Series(COUPES)	C30	2008	IAM(Integrated Audio Module)		V	V	V	V																											
C Series(COUPES)	C30	2008	CCM(Climate Control Module)		V			V																											
C Series(COUPES)	C30	2008	AUD(AUdio Module)		V			V																											
C Series(COUPES)	C30	2008	DDM(Driver Door Module)		V	V	V	V																											
C Series(COUPES)	C30	2008	PSM(Power Seat Module)		V		V	V																											
C Series(COUPES)	C30	2008	SWM(Steering Wheel Module)		V			V																											
C Series(COUPES)	C30	2007	System Search																																
C Series(COUPES)	C30	2007	ECM(Engine Control Module)		V			V																										V	V
C Series(COUPES)	C30	2007	TCM(Transmission Control Module)		V			V																											
C Series(COUPES)	C30	2007	ABS(Anti-Lock Brake System)		V			V																											
C Series(COUPES)	C30	2007	SRS(Supplemental Restraint System)		V			V																											
C Series(COUPES)	C30	2007	CEM(Central Electrical Module)		V			V																											
C Series(COUPES)	C30	2007	DIM(Driver Information Module)		V			V																											
C Series(COUPES)	C30	2007	DDM(Driver Door Module)		V			V																											
C Series(COUPES)	C30	2007	PDM(Passenger Door Module)		V			V																											
C Series(COUPES)	C30	2007	PSM(Power Seat Module)		V			V																											
C Series(COUPES)	C30	2007	CCM(Climate Control Module)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
C Series(COUPES)	C30	2007	SWM(Steering Wheel Module)		V			V																											
C Series(COUPES)	C70	C70 Convertible	2007	System Search																															
C Series(COUPES)	C70	C70 Convertible	2007	ECM(Engine Control Module)	V			V																										V	V
C Series(COUPES)	C70	C70 Convertible	2007	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2007	ABS(Anti-Lock Brake System)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2007	SRS(Supplemental Restraint System)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2007	CEM(Central Electrical Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2007	DIM(Driver Information Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2007	DDM(Driver Door Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2007	PDM(Passenger Door Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2007	PSM(Power Seat Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2007	CCM(Climate Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2007	SWM(Steering Wheel Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	System Search																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	ECM(Engine Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	ABS(Anti-Lock Brake System)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	SRS(Supplemental Restraint System)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	CEM(Central Electrical Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	DIM(Driver Information Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	DDM(Driver Door Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	PDM(Passenger Door Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	PSM(Power Seat Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	CCM(Climate Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	SWM(Steering Wheel Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2005	System Search																															
C Series(COUPES)	C70	C70 Convertible	2005	ECM(Engine Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2005	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2005	ABS(Anti-Lock Brake System)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2004	System Search																															
C Series(COUPES)	C70	C70 Convertible	2004	ECM(Engine Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2004	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2004	ABS(Anti-Lock Brake System)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2003	System Search																															
C Series(COUPES)	C70	C70 Convertible	2003	ECM(Engine Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2003	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2003	ABS(Anti-Lock Brake System)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2002	System Search																															
C Series(COUPES)	C70	C70 Convertible	2002	ECM(Engine Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2002	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2002	ABS(Anti-Lock Brake System)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2001	System Search																															
C Series(COUPES)	C70	C70 Convertible	2001	ECM(Engine Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2001	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2001	ABS(Anti-Lock Brake System)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2000	System Search																															

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
C Series(COUPES)	C70	C70 Convertible	2000	ECM(Engine Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2000	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	2000	ABS(Anti-Lock Brake System)	V			V																											
C Series(COUPES)	C70	C70 Convertible	1999	System Search																															
C Series(COUPES)	C70	C70 Convertible	1999	ECM(Engine Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	1999	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Convertible	1999	ABS(Anti-Lock Brake System)	V			V																											
C Series(COUPES)	C70	C70 Coupe	2002	System Search																															
C Series(COUPES)	C70	C70 Coupe	2002	ECM(Engine Control Module)	V			V																											
C Series(COUPES)	C70	C70 Coupe	2002	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Coupe	2002	ABS(Anti-Lock Brake System)	V			V																											
C Series(COUPES)	C70	C70 Coupe	2001	System Search																															
C Series(COUPES)	C70	C70 Coupe	2001	ECM(Engine Control Module)	V			V																											
C Series(COUPES)	C70	C70 Coupe	2001	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Coupe	2001	ABS(Anti-Lock Brake System)	V			V																											
C Series(COUPES)	C70	C70 Coupe	2000	System Search																															
C Series(COUPES)	C70	C70 Coupe	2000	ECM(Engine Control Module)	V			V																											
C Series(COUPES)	C70	C70 Coupe	2000	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Coupe	2000	ABS(Anti-Lock Brake System)	V			V																											
C Series(COUPES)	C70	C70 Coupe	1999	System Search																															
C Series(COUPES)	C70	C70 Coupe	1999	ECM(Engine Control Module)	V			V																											
C Series(COUPES)	C70	C70 Coupe	1999	TCM(Transmission Control Module)	V			V																											
C Series(COUPES)	C70	C70 Coupe	1999	ABS(Anti-Lock Brake System)	V			V																											
S Series(SEDANS)	Maintenance	BCM(Brake control module) Service function							V	V	V	V	V	V																					
S Series(SEDANS)	Maintenance	PBM(Parking brake module) Service function				V									V	V	V	V	V																
S Series(SEDANS)	Maintenance	Service Reminder Reset			V			V												V	V														
S Series(SEDANS)	Maintenance	Technical Information																					V	V											
S Series(SEDANS)	S40	2008	System Search																																
S Series(SEDANS)	S40	2008	ECM(Engine Control Module)		V			V																										V	V
S Series(SEDANS)	S40	2008	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S40	2008	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S40	2008	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S40	2008	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S40	2008	DIM(Driver Information Module)		V	V	V	V													V						V	V	V	V					
S Series(SEDANS)	S40	2008	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S40	2008	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S40	2008	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S40	2008	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S40	2008	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S40	2007	System Search																																
S Series(SEDANS)	S40	2007	ECM(Engine Control Module)		V			V																										V	V
S Series(SEDANS)	S40	2007	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S40	2007	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S40	2007	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S40	2007	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S40	2007	DIM(Driver Information Module)		V	V	V	V													V						V	V	V	V					

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S40	2007	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S40	2007	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S40	2007	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S40	2007	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S40	2007	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S40	2006	System Search																																
S Series(SEDANS)	S40	2006	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S40	2006	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S40	2006	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S40	2006	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S40	2006	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S40	2006	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S40	2006	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S40	2006	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S40	2006	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S40	2006	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S40	2006	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S40	2005	System Search																																
S Series(SEDANS)	S40	2005	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S40	2005	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S40	2005	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S40	2005	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S40	2005	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S40	2005	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S40	2005	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S40	2005	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S40	2005	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S40	2005	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S40	2005	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S40	2004(New Model)	System Search																																
S Series(SEDANS)	S40	2004(New Model)	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S40	2004(New Model)	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S40	2004(New Model)	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S40	2004(New Model)	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S40	2004(New Model)	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S40	2004(New Model)	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S40	2004(New Model)	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S40	2004(New Model)	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S40	2004(New Model)	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S40	2004(New Model)	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S40	2004(New Model)	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S60	2015	System Search																																
S Series(SEDANS)	S60	2015	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S60	2015	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
S Series(SEDANS)	S60	2015	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S60	2015	SAS(Steering Angle Sensor module)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S60	2015	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S60	2015	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S60	2015	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S60	2015	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S60	2015	FSM(Forward Sensing Module)		V	V		V																											
S Series(SEDANS)	S60	2015	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S60	2015	DIM(Driver Information Module)		V	V		V													V								V						
S Series(SEDANS)	S60	2015	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S60	2015	CEM(Central Electrical Module)		V	V	V	V																								V			
S Series(SEDANS)	S60	2015	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S60	2015	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S60	2015	PHM(PHone Module)		V	V		V																											
S Series(SEDANS)	S60	2015	IAM(Integrated Audio Module)		V	V		V																											
S Series(SEDANS)	S60	2015	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S60	2015	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S60	2015	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S60	2015	PSM(Power Seat Module)		V	V	V	V																											
S Series(SEDANS)	S60	2015	RDAR(Remote Digital Audio Receiver)		V	V		V																											
S Series(SEDANS)	S60	2015	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S60	2015	PAC(Parking Assistance Camera)		V			V																											
S Series(SEDANS)	S60	2015	SODR(Side Obstacle Detection control module Right)		V	V		V																											
S Series(SEDANS)	S60	2015	SODL(Side Obstacle Detection control module Left)		V	V		V																											
S Series(SEDANS)	S60	2014	System Search																																
S Series(SEDANS)	S60	2014	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S60	2014	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
S Series(SEDANS)	S60	2014	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S60	2014	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S60	2014	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S60	2014	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S60	2014	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S60	2014	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S60	2014	FSM(Forward Sensing Module)		V	V		V																											
S Series(SEDANS)	S60	2014	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S60	2014	DIM(Driver Information Module)		V	V		V													V								V						
S Series(SEDANS)	S60	2014	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S60	2014	CEM(Central Electrical Module)		V	V	V	V																								V			
S Series(SEDANS)	S60	2014	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S60	2014	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S60	2014	PHM(PHone Module)		V	V		V																											
S Series(SEDANS)	S60	2014	IAM(Integrated Audio Module)		V	V		V																											
S Series(SEDANS)	S60	2014	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S60	2014	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S60	2014	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S60	2014	PSM(Power Seat Module)		V	V	V	V																											
S Series(SEDANS)	S60	2014	RDAR(Remote Digital Audio Receiver)		V	V		V																											
S Series(SEDANS)	S60	2014	KVM(Keyless Vehicle Module)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S60	2014	PAC(Parking Assistance Camera)		V			V																											
S Series(SEDANS)	S60	2014	SODR(Side Obstacle Detection control module Right)		V	V		V																											
S Series(SEDANS)	S60	2014	SODL(Side Obstacle Detection control module Left)		V	V		V																											
S Series(SEDANS)	S60	2013	System Search																																
S Series(SEDANS)	S60	2013	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S60	2013	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
S Series(SEDANS)	S60	2013	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S60	2013	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S60	2013	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S60	2013	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S60	2013	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S60	2013	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S60	2013	FSM(Forward Sensing Module)		V	V		V																											
S Series(SEDANS)	S60	2013	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S60	2013	DIM(Driver Information Module)		V	V		V													V									V					
S Series(SEDANS)	S60	2013	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S60	2013	CEM(Central Electrical Module)		V	V	V	V																									V		
S Series(SEDANS)	S60	2013	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S60	2013	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S60	2013	PHM(PHone Module)		V	V		V																											
S Series(SEDANS)	S60	2013	IAM(Integrated Audio Module)		V	V		V																											
S Series(SEDANS)	S60	2013	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S60	2013	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S60	2013	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S60	2013	PSM(Power Seat Module)		V	V	V	V																											
S Series(SEDANS)	S60	2013	RDAR(Remote Digital Audio Receiver)		V	V		V																											
S Series(SEDANS)	S60	2013	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S60	2013	PAC(Parking Assistance Camera)		V			V																											
S Series(SEDANS)	S60	2013	SODR(Side Obstacle Detection control module Right)		V	V		V																											
S Series(SEDANS)	S60	2013	SODL(Side Obstacle Detection control module Left)		V	V		V																											
S Series(SEDANS)	S60	2012	System Search																																
S Series(SEDANS)	S60	2012	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S60	2012	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
S Series(SEDANS)	S60	2012	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S60	2012	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S60	2012	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S60	2012	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S60	2012	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S60	2012	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S60	2012	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S60	2012	DIM(Driver Information Module)		V	V		V													V									V					
S Series(SEDANS)	S60	2012	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S60	2012	CEM(Central Electrical Module)		V	V	V	V																									V		
S Series(SEDANS)	S60	2012	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S60	2012	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S60	2012	IAM(Integrated Audio Module)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S60	2012	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S60	2012	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S60	2012	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S60	2012	PSM(Power Seat Module)		V	V	V	V																											
S Series(SEDANS)	S60	2012	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S60	2011	System Search																																
S Series(SEDANS)	S60	2011	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S60	2011	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
S Series(SEDANS)	S60	2011	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S60	2011	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S60	2011	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S60	2011	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S60	2011	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S60	2011	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S60	2011	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S60	2011	DIM(Driver Information Module)		V	V		V													V									V					
S Series(SEDANS)	S60	2011	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S60	2011	CEM(Central Electrical Module)		V	V	V	V																									V		
S Series(SEDANS)	S60	2011	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S60	2011	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S60	2011	IAM(Integrated Audio Module)		V	V		V																											
S Series(SEDANS)	S60	2011	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S60	2011	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S60	2011	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S60	2011	PSM(Power Seat Module)		V	V	V	V																											
S Series(SEDANS)	S60	2011	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S60	2010	System Search																																
S Series(SEDANS)	S60	2010	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S60	2010	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
S Series(SEDANS)	S60	2010	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S60	2010	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S60	2010	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S60	2010	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S60	2010	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S60	2010	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S60	2010	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S60	2010	DIM(Driver Information Module)		V	V		V													V									V					
S Series(SEDANS)	S60	2010	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S60	2010	CEM(Central Electrical Module)		V	V	V	V																									V		
S Series(SEDANS)	S60	2010	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S60	2010	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S60	2010	IAM(Integrated Audio Module)		V	V		V																											
S Series(SEDANS)	S60	2010	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S60	2010	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S60	2010	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S60	2010	PSM(Power Seat Module)		V	V	V	V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S60	2010	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S60	2009	System Search																																
S Series(SEDANS)	S60	2009	ECM(Engine Control Module)		V			V																										V	V
S Series(SEDANS)	S60	2009	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S60	2009	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S60	2009	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S60	2009	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S60	2009	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S60	2009	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S60	2009	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S60	2009	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S60	2009	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S60	2009	SAS(Steering Wheel Angle Sensor Module)		V			V																											
S Series(SEDANS)	S60	2009	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S60	2009	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S60	2009	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S60	2008	System Search																																
S Series(SEDANS)	S60	2008	ECM(Engine Control Module)		V			V																										V	V
S Series(SEDANS)	S60	2008	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S60	2008	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S60	2008	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S60	2008	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S60	2008	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S60	2008	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S60	2008	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S60	2008	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S60	2008	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S60	2008	SAS(Steering Wheel Angle Sensor Module)		V			V																											
S Series(SEDANS)	S60	2008	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S60	2008	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S60	2008	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S60	2007	System Search																																
S Series(SEDANS)	S60	2007	ECM(Engine Control Module)		V			V																										V	V
S Series(SEDANS)	S60	2007	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S60	2007	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S60	2007	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S60	2007	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S60	2007	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S60	2007	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S60	2007	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S60	2007	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S60	2007	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S60	2007	SAS(Steering Wheel Angle Sensor Module)		V			V																											
S Series(SEDANS)	S60	2007	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S60	2007	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S60	2007	AUM(Audio Module)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S60	2006	System Search																																
S Series(SEDANS)	S60	2006	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S60	2006	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S60	2006	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S60	2006	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S60	2006	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S60	2006	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S60	2006	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S60	2006	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S60	2006	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S60	2006	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S60	2006	SAS(Steering Wheel Angle Sensor Module)		V			V																											
S Series(SEDANS)	S60	2006	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S60	2006	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S60	2006	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S60	2005	System Search																																
S Series(SEDANS)	S60	2005	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S60	2005	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S60	2005	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S60	2005	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S60	2005	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S60	2005	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S60	2005	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S60	2005	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S60	2005	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S60	2005	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S60	2005	SAS(Steering Wheel Angle Sensor Module)		V			V																											
S Series(SEDANS)	S60	2005	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S60	2005	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S60	2005	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S60	2004	System Search																																
S Series(SEDANS)	S60	2004	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S60	2004	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S60	2004	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S60	2004	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S60	2004	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S60	2004	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S60	2004	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S60	2004	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S60	2004	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S60	2004	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S60	2004	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S60	2004	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S60	2004	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S60	2004	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S60	2003	System Search																																

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S60	2003	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S60	2003	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S60	2003	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S60	2003	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S60	2003	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S60	2003	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S60	2003	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S60	2003	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S60	2003	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S60	2003	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S60	2003	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S60	2003	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S60	2003	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S60	2003	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S60	2002	System Search																																
S Series(SEDANS)	S60	2002	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S60	2002	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S60	2002	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S60	2002	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S60	2002	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S60	2002	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S60	2002	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S60	2002	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S60	2002	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S60	2002	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S60	2002	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S60	2002	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S60	2002	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S60	2002	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S60	2001	System Search																																
S Series(SEDANS)	S60	2001	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S60	2001	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S60	2001	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S60	2001	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S60	2001	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S60	2001	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S60	2001	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S60	2001	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S60	2001	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S60	2001	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S60	2001	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S60	2001	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S60	2001	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S60	2001	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S70	2000	System Search																																
S Series(SEDANS)	S70	2000	ECM(Engine Control Module)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S70	2000	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S70	2000	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S70	1999	System Search																																
S Series(SEDANS)	S70	1999	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S70	1999	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S70	1999	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S80	2014	System Search																																
S Series(SEDANS)	S80	2014	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S80	2014	TCM(Transmission Control Module)	TF-80SC	V	V	V	V															V	V	V	V									
S Series(SEDANS)	S80	2014	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S80	2014	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S80	2014	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S80	2014	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S80	2014	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S80	2014	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S80	2014	FSM(Forward Sensing Module)		V	V		V																											
S Series(SEDANS)	S80	2014	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S80	2014	DIM(Driver Information Module)		V	V		V													V									V					
S Series(SEDANS)	S80	2014	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S80	2014	CEM(Central Electrical Module)		V	V	V	V																								V			
S Series(SEDANS)	S80	2014	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S80	2014	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S80	2014	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S80	2014	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S80	2014	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S80	2014	PSM(Power Seat Module)		V	V	V	V																											
S Series(SEDANS)	S80	2014	DEM(Differential Electronic Module)		V	V		V																											
S Series(SEDANS)	S80	2014	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S80	2014	POT(Power operated tailgate module)		V	V		V																											
S Series(SEDANS)	S80	2014	SODR(Side Obstacle Detection control module Right)		V	V		V																											
S Series(SEDANS)	S80	2014	SODL(Side Obstacle Detection control module Left)		V	V		V																											
S Series(SEDANS)	S80	2014	RDAR(Remote Digital Audio Receiver)		V	V		V																											
S Series(SEDANS)	S80	2014	HCM(Headlamp control module)		V	V		V																											
S Series(SEDANS)	S80	2014	BPM(Bluetooth phone module)		V			V																											
S Series(SEDANS)	S80	2013	System Search																																
S Series(SEDANS)	S80	2013	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S80	2013	TCM(Transmission Control Module)	TF-80SC	V	V	V	V															V	V	V	V									
S Series(SEDANS)	S80	2013	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S80	2013	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S80	2013	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S80	2013	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S80	2013	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S80	2013	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S80	2013	FSM(Forward Sensing Module)		V	V		V																											
S Series(SEDANS)	S80	2013	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S80	2013	DIM(Driver Information Module)		V	V		V													V									V					

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S80	2013	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S80	2013	CEM(Central Electrical Module)		V	V	V	V																									V		
S Series(SEDANS)	S80	2013	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S80	2013	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S80	2013	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S80	2013	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S80	2013	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S80	2013	PSM(Power Seat Module)		V	V	V	V																											
S Series(SEDANS)	S80	2013	DEM(Differential Electronic Module)		V	V		V																											
S Series(SEDANS)	S80	2013	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S80	2013	POT(Power operated tailgate module)		V	V		V																											
S Series(SEDANS)	S80	2013	SODR(Side Obstacle Detection control module Right)		V	V		V																											
S Series(SEDANS)	S80	2013	SODL(Side Obstacle Detection control module Left)		V	V		V																											
S Series(SEDANS)	S80	2013	RDAR(Remote Digital Audio Receiver)		V	V		V																											
S Series(SEDANS)	S80	2013	HCM(Headlamp control module)		V	V		V																											
S Series(SEDANS)	S80	2013	BPM(Bluetooth phone module)		V			V																											
S Series(SEDANS)	S80	2012	System Search																																
S Series(SEDANS)	S80	2012	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S80	2012	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
S Series(SEDANS)	S80	2012	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S80	2012	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S80	2012	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S80	2012	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S80	2012	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S80	2012	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S80	2012	FSM(Forward Sensing Module)		V	V		V																											
S Series(SEDANS)	S80	2012	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S80	2012	DIM(Driver Information Module)		V	V		V													V									V					
S Series(SEDANS)	S80	2012	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S80	2012	CEM(Central Electrical Module)		V	V	V	V																									V		
S Series(SEDANS)	S80	2012	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S80	2012	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S80	2012	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S80	2012	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S80	2012	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S80	2012	PSM(Power Seat Module)		V	V	V	V																											
S Series(SEDANS)	S80	2012	DEM(Differential Electronic Module)		V	V		V																											
S Series(SEDANS)	S80	2012	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S80	2012	POT(Power operated tailgate module)		V	V		V																											
S Series(SEDANS)	S80	2012	SODR(Side Obstacle Detection control module Right)		V	V		V																											
S Series(SEDANS)	S80	2012	SODL(Side Obstacle Detection control module Left)		V	V		V																											
S Series(SEDANS)	S80	2012	RDAR(Remote Digital Audio Receiver)		V	V		V																											
S Series(SEDANS)	S80	2012	HCM(Headlamp control module)		V	V		V																											
S Series(SEDANS)	S80	2012	BPM(Bluetooth phone module)		V			V																											
S Series(SEDANS)	S80	2011	System Search																																
S Series(SEDANS)	S80	2011	ECM(Engine Control Module)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S80	2011	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
S Series(SEDANS)	S80	2011	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S80	2011	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S80	2011	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S80	2011	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S80	2011	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S80	2011	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S80	2011	FSM(Forward Sensing Module)		V	V		V																											
S Series(SEDANS)	S80	2011	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S80	2011	DIM(Driver Information Module)		V	V		V													V									V					
S Series(SEDANS)	S80	2011	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S80	2011	CEM(Central Electrical Module)		V	V	V	V																									V		
S Series(SEDANS)	S80	2011	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S80	2011	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S80	2011	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S80	2011	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S80	2011	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S80	2011	PSM(Power Seat Module)		V	V	V	V																											
S Series(SEDANS)	S80	2011	DEM(Differential Electronic Module)		V	V		V																											
S Series(SEDANS)	S80	2011	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S80	2011	POT(Power operated tailgate module)		V	V		V																											
S Series(SEDANS)	S80	2011	SODR(Side Obstacle Detection control module Right)		V	V		V																											
S Series(SEDANS)	S80	2011	SODL(Side Obstacle Detection control module Left)		V	V		V																											
S Series(SEDANS)	S80	2011	RDAR(Remote Digital Audio Receiver)		V	V		V																											
S Series(SEDANS)	S80	2011	HCM(Headlamp control module)		V	V		V																											
S Series(SEDANS)	S80	2011	BPM(Bluetooth phone module)		V			V																											
S Series(SEDANS)	S80	2010	System Search																																
S Series(SEDANS)	S80	2010	ECM(Engine Control Module)		V			V																										V	V
S Series(SEDANS)	S80	2010	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
S Series(SEDANS)	S80	2010	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S80	2010	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S80	2010	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S80	2010	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S80	2010	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S80	2010	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S80	2010	FSM(Forward Sensing Module)		V	V		V																											
S Series(SEDANS)	S80	2010	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S80	2010	DIM(Driver Information Module)		V	V		V													V									V					
S Series(SEDANS)	S80	2010	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S80	2010	CEM(Central Electrical Module)		V	V	V	V																									V		
S Series(SEDANS)	S80	2010	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S80	2010	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S80	2010	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S80	2010	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S80	2010	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S80	2010	PSM(Power Seat Module)		V	V	V	V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S80	2010	DEM(Differential Electronic Module)		V	V		V																											
S Series(SEDANS)	S80	2010	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S80	2010	POT(Power operated tailgate module)		V	V		V																											
S Series(SEDANS)	S80	2010	SODR(Side Obstacle Detection control module Right)		V	V		V																											
S Series(SEDANS)	S80	2010	SODL(Side Obstacle Detection control module Left)		V	V		V																											
S Series(SEDANS)	S80	2010	RDAR(Remote Digital Audio Receiver)		V	V		V																											
S Series(SEDANS)	S80	2010	HCM(Headlamp control module)		V	V		V																											
S Series(SEDANS)	S80	2010	BPM(Bluetooth phone module)		V			V																											
S Series(SEDANS)	S80	2009	System Search																																
S Series(SEDANS)	S80	2009	ECM(Engine Control Module)		V			V																										V	V
S Series(SEDANS)	S80	2009	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
S Series(SEDANS)	S80	2009	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S80	2009	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S80	2009	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S80	2009	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S80	2009	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S80	2009	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S80	2009	FSM(Forward Sensing Module)		V	V		V																											
S Series(SEDANS)	S80	2009	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S80	2009	DIM(Driver Information Module)		V	V		V													V									V					
S Series(SEDANS)	S80	2009	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S80	2009	CEM(Central Electrical Module)		V	V	V	V																								V			
S Series(SEDANS)	S80	2009	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S80	2009	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S80	2009	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S80	2009	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S80	2009	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S80	2009	PSM(Power Seat Module)		V	V	V	V																											
S Series(SEDANS)	S80	2009	DEM(Differential Electronic Module)		V	V		V																											
S Series(SEDANS)	S80	2009	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S80	2009	POT(Power operated tailgate module)		V	V		V																											
S Series(SEDANS)	S80	2009	SODR(Side Obstacle Detection control module Right)		V	V		V																											
S Series(SEDANS)	S80	2009	SODL(Side Obstacle Detection control module Left)		V	V		V																											
S Series(SEDANS)	S80	2009	RDAR(Remote Digital Audio Receiver)		V	V		V																											
S Series(SEDANS)	S80	2009	HCM(Headlamp control module)		V	V		V																											
S Series(SEDANS)	S80	2009	BPM(Bluetooth phone module)		V			V																											
S Series(SEDANS)	S80	2008	System Search																																
S Series(SEDANS)	S80	2008	ECM(Engine Control Module)		V			V																										V	V
S Series(SEDANS)	S80	2008	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
S Series(SEDANS)	S80	2008	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S80	2008	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S80	2008	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S80	2008	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S80	2008	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S80	2008	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S80	2008	FSM(Forward Sensing Module)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S80	2008	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S80	2008	DIM(Driver Information Module)		V	V		V													V									V					
S Series(SEDANS)	S80	2008	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S80	2008	CEM(Central Electrical Module)		V	V	V	V																									V		
S Series(SEDANS)	S80	2008	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S80	2008	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S80	2008	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S80	2008	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S80	2008	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S80	2008	PSM(Power Seat Module)		V	V	V	V																											
S Series(SEDANS)	S80	2008	DEM(Differential Electronic Module)		V	V		V																											
S Series(SEDANS)	S80	2008	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S80	2008	POT(Power operated tailgate module)		V	V		V																											
S Series(SEDANS)	S80	2008	SODR(Side Obstacle Detection control module Right)		V	V		V																											
S Series(SEDANS)	S80	2008	SODL(Side Obstacle Detection control module Left)		V	V		V																											
S Series(SEDANS)	S80	2008	RDAR(Remote Digital Audio Receiver)		V	V		V																											
S Series(SEDANS)	S80	2008	HCM(Headlamp control module)		V	V		V																											
S Series(SEDANS)	S80	2008	BPM(Bluetooth phone module)		V			V																											
S Series(SEDANS)	S80	2007	System Search																																
S Series(SEDANS)	S80	2007	ECM(Engine Control Module)		V			V																										V	V
S Series(SEDANS)	S80	2007	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
S Series(SEDANS)	S80	2007	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
S Series(SEDANS)	S80	2007	SAS(Steering Angle Sensor module)		V	V		V																											
S Series(SEDANS)	S80	2007	BCM(Brake Control Module)		V	V	V	V																											
S Series(SEDANS)	S80	2007	PBM(Park Brake Module)		V	V		V																											
S Series(SEDANS)	S80	2007	SRS(Supplemental Restraint System)		V	V		V																											
S Series(SEDANS)	S80	2007	PSCM(Power Steering Control Module)		V	V		V																											
S Series(SEDANS)	S80	2007	FSM(Forward Sensing Module)		V	V		V																											
S Series(SEDANS)	S80	2007	CVM(Closing Velocity Module)		V	V		V																											
S Series(SEDANS)	S80	2007	DIM(Driver Information Module)		V	V		V													V									V					
S Series(SEDANS)	S80	2007	PAM(Parking Assistance Module)		V	V		V																											
S Series(SEDANS)	S80	2007	CEM(Central Electrical Module)		V	V	V	V																									V		
S Series(SEDANS)	S80	2007	ICM(Infotainment Control Module)		V	V		V																											
S Series(SEDANS)	S80	2007	PDM(Passenger door module)		V	V	V	V																											
S Series(SEDANS)	S80	2007	CCM(Climate control module)		V	V	V	V																											
S Series(SEDANS)	S80	2007	AUD(AUdio Module)		V			V																											
S Series(SEDANS)	S80	2007	DDM(Driver Door Module)		V	V	V	V																											
S Series(SEDANS)	S80	2007	PSM(Power Seat Module)		V	V	V	V																											
S Series(SEDANS)	S80	2007	DEM(Differential Electronic Module)		V	V		V																											
S Series(SEDANS)	S80	2007	KVM(Keyless Vehicle Module)		V	V		V																											
S Series(SEDANS)	S80	2007	POT(Power operated tailgate module)		V	V		V																											
S Series(SEDANS)	S80	2007	SODR(Side Obstacle Detection control module Right)		V	V		V																											
S Series(SEDANS)	S80	2007	SODL(Side Obstacle Detection control module Left)		V	V		V																											
S Series(SEDANS)	S80	2007	RDAR(Remote Digital Audio Receiver)		V	V		V																											
S Series(SEDANS)	S80	2007	HCM(Headlamp control module)		V	V		V																											
S Series(SEDANS)	S80	2007	BPM(Bluetooth phone module)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S80	2006	System Search																																
S Series(SEDANS)	S80	2006	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S80	2006	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S80	2006	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S80	2006	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S80	2006	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S80	2006	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S80	2006	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S80	2006	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S80	2006	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S80	2006	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S80	2006	SAS(Steering Wheel Angle Sensor Module)		V			V																											
S Series(SEDANS)	S80	2006	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S80	2006	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S80	2006	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S80	2005	System Search																																
S Series(SEDANS)	S80	2005	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S80	2005	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S80	2005	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S80	2005	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S80	2005	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S80	2005	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S80	2005	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S80	2005	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S80	2005	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S80	2005	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S80	2005	SAS(Steering Wheel Angle Sensor Module)		V			V																											
S Series(SEDANS)	S80	2005	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S80	2005	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S80	2005	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S80	2004	System Search																																
S Series(SEDANS)	S80	2004	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S80	2004	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S80	2004	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S80	2004	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S80	2004	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S80	2004	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S80	2004	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S80	2004	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S80	2004	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S80	2004	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S80	2004	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S80	2004	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S80	2004	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S80	2004	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S80	2003	System Search																																

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S80	2003	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S80	2003	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S80	2003	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S80	2003	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S80	2003	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S80	2003	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S80	2003	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S80	2003	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S80	2003	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S80	2003	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S80	2003	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S80	2003	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S80	2003	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S80	2003	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S80	2002	System Search																																
S Series(SEDANS)	S80	2002	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S80	2002	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S80	2002	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S80	2002	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S80	2002	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S80	2002	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S80	2002	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S80	2002	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S80	2002	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S80	2002	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S80	2002	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S80	2002	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S80	2002	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S80	2002	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S80	2001	System Search																																
S Series(SEDANS)	S80	2001	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S80	2001	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S80	2001	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S80	2001	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S80	2001	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S80	2001	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S80	2001	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S80	2001	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S80	2001	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S80	2001	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S80	2001	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S80	2001	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S80	2001	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S80	2001	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S80	2000	System Search																																
S Series(SEDANS)	S80	2000	ECM(Engine Control Module)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
S Series(SEDANS)	S80	2000	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S80	2000	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S80	2000	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S80	2000	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S80	2000	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S80	2000	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S80	2000	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S80	2000	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S80	2000	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S80	2000	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S80	2000	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S80	2000	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S80	2000	AUM(Audio Module)		V			V																											
S Series(SEDANS)	S80	1999	System Search																																
S Series(SEDANS)	S80	1999	ECM(Engine Control Module)		V			V																											
S Series(SEDANS)	S80	1999	TCM(Transmission Control Module)		V			V																											
S Series(SEDANS)	S80	1999	ABS(Anti-Lock Brake System)		V			V																											
S Series(SEDANS)	S80	1999	SRS(Supplemental Restraint System)		V			V																											
S Series(SEDANS)	S80	1999	CEM(Central Electrical Module)		V			V																											
S Series(SEDANS)	S80	1999	DIM(Driver Information Module)		V			V																											
S Series(SEDANS)	S80	1999	DDM(Driver Door Module)		V			V																											
S Series(SEDANS)	S80	1999	PDM(Passenger Door Module)		V			V																											
S Series(SEDANS)	S80	1999	PSM(Power Seat Module)		V			V																											
S Series(SEDANS)	S80	1999	CCM(Climate Control Module)		V			V																											
S Series(SEDANS)	S80	1999	SWM(Steering Wheel Module)		V			V																											
S Series(SEDANS)	S80	1999	UEM(Up Electrical Module)		V			V																											
S Series(SEDANS)	S80	1999	REM(Rear Electrical Module)		V			V																											
S Series(SEDANS)	S80	1999	AUM(Audio Module)		V			V																											
V Series(WAGONS)	Maintenance	BCM(Brake control module) Service function							V	V	V	V	V	V																					
V Series(WAGONS)	Maintenance	PBM(Parking brake module) Service function				V									V	V	V	V	V																
V Series(WAGONS)	Maintenance	Service Reminder Reset			V			V												V	V														
V Series(WAGONS)	Maintenance	Technical Information																				V	V												
V Series(WAGONS)	V40	2014	System Search																																
V Series(WAGONS)	V40	2014	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V40	2014	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V40	2014	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V40	2014	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V40	2014	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V40	2014	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V40	2014	PSCM(Power Steering Control Module)		V	V		V																											
V Series(WAGONS)	V40	2014	CVM(Closing Velocity Module)		V	V		V																											
V Series(WAGONS)	V40	2014	DIM(Driver Information Module)		V	V		V													V									V					
V Series(WAGONS)	V40	2014	FSM(Forward Sensing Module)		V	V		V																											
V Series(WAGONS)	V40	2014	PAM(Parking Assistance Module)		V	V		V																											
V Series(WAGONS)	V40	2014	CEM(Central Electrical Module)		V	V	V	V																								V			
V Series(WAGONS)	V40	2014	ICM(Infotainment Control Module)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
V Series(WAGONS)	V40	2014	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V40	2014	IAM(Integrated Audio Module)		V	V		V																											
V Series(WAGONS)	V40	2014	CCM(Climate control module)		V	V	V	V																											
V Series(WAGONS)	V40	2014	AUD(AUdio Module)		V			V																											
V Series(WAGONS)	V40	2014	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V40	2014	PPM(Pedestrian Protection Module)		V	V		V																											
V Series(WAGONS)	V40	2014	SODR(Side Obstacle Detection control module Right)		V	V		V																											
V Series(WAGONS)	V40	2014	SODL(Side Obstacle Detection control module Left)		V	V		V																											
V Series(WAGONS)	V40	2013	System Search																																
V Series(WAGONS)	V40	2013	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V40	2013	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V40	2013	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V40	2013	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V40	2013	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V40	2013	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V40	2013	PSCM(Power Steering Control Module)		V	V		V																											
V Series(WAGONS)	V40	2013	CVM(Closing Velocity Module)		V	V		V																											
V Series(WAGONS)	V40	2013	DIM(Driver Information Module)		V	V		V													V									V					
V Series(WAGONS)	V40	2013	PAM(Parking Assistance Module)		V	V		V																											
V Series(WAGONS)	V40	2013	FSM(Forward Sensing Module)		V	V		V																											
V Series(WAGONS)	V40	2013	CEM(Central Electrical Module)		V	V	V	V																								V			
V Series(WAGONS)	V40	2013	ICM(Infotainment Control Module)		V	V		V																											
V Series(WAGONS)	V40	2013	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V40	2013	IAM(Integrated Audio Module)		V	V		V																											
V Series(WAGONS)	V40	2013	CCM(Climate control module)		V	V	V	V																											
V Series(WAGONS)	V40	2013	AUD(AUdio Module)		V			V																											
V Series(WAGONS)	V40	2013	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V40	2013	PPM(Pedestrian Protection Module)		V	V		V																											
V Series(WAGONS)	V40	2013	SODR(Side Obstacle Detection control module Right)		V	V		V																											
V Series(WAGONS)	V40	2013	SODL(Side Obstacle Detection control module Left)		V	V		V																											
V Series(WAGONS)	V40	2012	System Search																																
V Series(WAGONS)	V40	2012	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V40	2012	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V40	2012	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V40	2012	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V40	2012	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V40	2012	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V40	2012	PSCM(Power Steering Control Module)		V	V		V																											
V Series(WAGONS)	V40	2012	CVM(Closing Velocity Module)		V	V		V																											
V Series(WAGONS)	V40	2012	DIM(Driver Information Module)		V	V		V													V									V					
V Series(WAGONS)	V40	2012	PAM(Parking Assistance Module)		V	V		V																											
V Series(WAGONS)	V40	2012	FSM(Forward Sensing Module)		V	V		V																											
V Series(WAGONS)	V40	2012	CEM(Central Electrical Module)		V	V	V	V																								V			
V Series(WAGONS)	V40	2012	ICM(Infotainment Control Module)		V	V		V																											
V Series(WAGONS)	V40	2012	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V40	2012	IAM(Integrated Audio Module)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
V Series(WAGONS)	V40	2012	CCM(Climate control module)		V	V	V	V																											
V Series(WAGONS)	V40	2012	AUD(AUdio Module)		V			V																											
V Series(WAGONS)	V40	2012	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V40	2012	PPM(Pedestrian Protection Module)		V	V		V																											
V Series(WAGONS)	V40	2012	SODR(Side Obstacle Detection control module Right)		V	V		V																											
V Series(WAGONS)	V40	2012	SODL(Side Obstacle Detection control module Left)		V	V		V																											
V Series(WAGONS)	V50	2012	System Search																																
V Series(WAGONS)	V50	2012	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V50	2012	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V50	2012	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V50	2012	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V50	2012	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V50	2012	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V50	2012	DIM(Driver Information Module)		V	V	V	V													V							V	V	V	V				
V Series(WAGONS)	V50	2012	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V50	2012	CCM(Climate control module)		V	V		V																											
V Series(WAGONS)	V50	2012	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V50	2012	EPS(Electrical power steering module)		V	V		V																											
V Series(WAGONS)	V50	2012	HCM(Headlamp control module)		V	V		V																											
V Series(WAGONS)	V50	2011	System Search																																
V Series(WAGONS)	V50	2011	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V50	2011	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V50	2011	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V50	2011	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V50	2011	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V50	2011	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V50	2011	DIM(Driver Information Module)		V	V	V	V													V							V	V	V	V				
V Series(WAGONS)	V50	2011	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V50	2011	CCM(Climate control module)		V	V		V																											
V Series(WAGONS)	V50	2011	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V50	2011	EPS(Electrical power steering module)		V	V		V																											
V Series(WAGONS)	V50	2011	HCM(Headlamp control module)		V	V		V																											
V Series(WAGONS)	V50	2010	System Search																																
V Series(WAGONS)	V50	2010	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V50	2010	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V50	2010	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V50	2010	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V50	2010	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V50	2010	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V50	2010	DIM(Driver Information Module)		V	V	V	V													V							V	V	V	V				
V Series(WAGONS)	V50	2010	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V50	2010	CCM(Climate control module)		V	V		V																											
V Series(WAGONS)	V50	2010	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V50	2010	EPS(Electrical power steering module)		V	V		V																											
V Series(WAGONS)	V50	2010	HCM(Headlamp control module)		V	V		V																											
V Series(WAGONS)	V50	2010	ABS(Anti-Lock Brake System)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
V Series(WAGONS)	V50	2010	CEM(Central Electrical Module)		V			V																											
V Series(WAGONS)	V50	2010	PSM(Power Seat Module)		V			V																											
V Series(WAGONS)	V50	2010	SWM(Steering Wheel Module)		V			V																											
V Series(WAGONS)	V50	2009	System Search																																
V Series(WAGONS)	V50	2009	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V50	2009	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V50	2009	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V50	2009	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V50	2009	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V50	2009	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V50	2009	DIM(Driver Information Module)		V	V	V	V													V							V	V	V	V				
V Series(WAGONS)	V50	2009	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V50	2009	CCM(Climate control module)		V	V		V																											
V Series(WAGONS)	V50	2009	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V50	2009	EPS(Electrical power steering module)		V	V		V																											
V Series(WAGONS)	V50	2009	HCM(Headlamp control module)		V	V		V																											
V Series(WAGONS)	V50	2009	ABS(Anti-Lock Brake System)		V			V																											
V Series(WAGONS)	V50	2009	CEM(Central Electrical Module)		V			V																											
V Series(WAGONS)	V50	2009	PSM(Power Seat Module)		V			V																											
V Series(WAGONS)	V50	2009	SWM(Steering Wheel Module)		V			V																											
V Series(WAGONS)	V50	2008	System Search																																
V Series(WAGONS)	V50	2008	ECM(Engine Control Module)		V			V																										V	V
V Series(WAGONS)	V50	2008	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V50	2008	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V50	2008	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V50	2008	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V50	2008	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V50	2008	DIM(Driver Information Module)		V	V	V	V													V							V	V	V	V				
V Series(WAGONS)	V50	2008	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V50	2008	CCM(Climate control module)		V	V		V																											
V Series(WAGONS)	V50	2008	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V50	2008	EPS(Electrical power steering module)		V	V		V																											
V Series(WAGONS)	V50	2008	HCM(Headlamp control module)		V	V		V																											
V Series(WAGONS)	V50	2008	ABS(Anti-Lock Brake System)		V			V																											
V Series(WAGONS)	V50	2008	CEM(Central Electrical Module)		V			V																											
V Series(WAGONS)	V50	2008	PSM(Power Seat Module)		V			V																											
V Series(WAGONS)	V50	2008	SWM(Steering Wheel Module)		V			V																											
V Series(WAGONS)	V50	2007	System Search																																
V Series(WAGONS)	V50	2007	ECM(Engine Control Module)		V			V																										V	V
V Series(WAGONS)	V50	2007	TCM(Transmission Control Module)		V			V																											
V Series(WAGONS)	V50	2007	ABS(Anti-Lock Brake System)		V			V																											
V Series(WAGONS)	V50	2007	SRS(Supplemental Restraint System)		V			V																											
V Series(WAGONS)	V50	2007	CEM(Central Electrical Module)		V			V																											
V Series(WAGONS)	V50	2007	DIM(Driver Information Module)		V			V																											
V Series(WAGONS)	V50	2007	DDM(Driver Door Module)		V			V																											
V Series(WAGONS)	V50	2007	PDM(Passenger Door Module)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
V Series(WAGONS)	V50	2007	PSM(Power Seat Module)		V			V																											
V Series(WAGONS)	V50	2007	CCM(Climate Control Module)		V			V																											
V Series(WAGONS)	V50	2007	SWM(Steering Wheel Module)		V			V																											
V Series(WAGONS)	V50	2006	System Search																																
V Series(WAGONS)	V50	2006	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V50	2006	TCM(Transmission Control Module)		V			V																											
V Series(WAGONS)	V50	2006	ABS(Anti-Lock Brake System)		V			V																											
V Series(WAGONS)	V50	2006	SRS(Supplemental Restraint System)		V			V																											
V Series(WAGONS)	V50	2006	CEM(Central Electrical Module)		V			V																											
V Series(WAGONS)	V50	2006	DIM(Driver Information Module)		V			V																											
V Series(WAGONS)	V50	2006	DDM(Driver Door Module)		V			V																											
V Series(WAGONS)	V50	2006	PDM(Passenger Door Module)		V			V																											
V Series(WAGONS)	V50	2006	PSM(Power Seat Module)		V			V																											
V Series(WAGONS)	V50	2006	CCM(Climate Control Module)		V			V																											
V Series(WAGONS)	V50	2006	SWM(Steering Wheel Module)		V			V																											
V Series(WAGONS)	V50	2005	System Search																																
V Series(WAGONS)	V50	2005	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V50	2005	TCM(Transmission Control Module)		V			V																											
V Series(WAGONS)	V50	2005	ABS(Anti-Lock Brake System)		V			V																											
V Series(WAGONS)	V50	2005	SRS(Supplemental Restraint System)		V			V																											
V Series(WAGONS)	V50	2005	CEM(Central Electrical Module)		V			V																											
V Series(WAGONS)	V50	2005	DIM(Driver Information Module)		V			V																											
V Series(WAGONS)	V50	2005	DDM(Driver Door Module)		V			V																											
V Series(WAGONS)	V50	2005	PDM(Passenger Door Module)		V			V																											
V Series(WAGONS)	V50	2005	PSM(Power Seat Module)		V			V																											
V Series(WAGONS)	V50	2005	CCM(Climate Control Module)		V			V																											
V Series(WAGONS)	V50	2005	SWM(Steering Wheel Module)		V			V																											
V Series(WAGONS)	V50	2004	System Search																																
V Series(WAGONS)	V50	2004	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V50	2004	TCM(Transmission Control Module)		V			V																											
V Series(WAGONS)	V50	2004	ABS(Anti-Lock Brake System)		V			V																											
V Series(WAGONS)	V50	2004	SRS(Supplemental Restraint System)		V			V																											
V Series(WAGONS)	V50	2004	CEM(Central Electrical Module)		V			V																											
V Series(WAGONS)	V50	2004	DIM(Driver Information Module)		V			V																											
V Series(WAGONS)	V50	2004	DDM(Driver Door Module)		V			V																											
V Series(WAGONS)	V50	2004	PDM(Passenger Door Module)		V			V																											
V Series(WAGONS)	V50	2004	PSM(Power Seat Module)		V			V																											
V Series(WAGONS)	V50	2004	CCM(Climate Control Module)		V			V																											
V Series(WAGONS)	V50	2004	SWM(Steering Wheel Module)		V			V																											
V Series(WAGONS)	V60	2014	System Search																																
V Series(WAGONS)	V60	2014	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V60	2014	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V60	2014	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V60	2014	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V60	2014	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V60	2014	PBM(Park Brake Module)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
V Series(WAGONS)	V60	2014	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V60	2014	PSCM(Power Steering Control Module)		V	V		V																											
V Series(WAGONS)	V60	2014	FSM(Forward Sensing Module)		V	V		V																											
V Series(WAGONS)	V60	2014	CVM(Closing Velocity Module)		V	V		V																											
V Series(WAGONS)	V60	2014	DIM(Driver Information Module)		V	V		V													V								V						
V Series(WAGONS)	V60	2014	SUM(SUspension Module)		V	V	V	V																											
V Series(WAGONS)	V60	2014	PAM(Parking Assistance Module)		V	V		V																											
V Series(WAGONS)	V60	2014	CEM(Central Electrical Module)		V	V	V	V																									V		
V Series(WAGONS)	V60	2014	ICM(Infotainment Control Module)		V	V		V																											
V Series(WAGONS)	V60	2014	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V60	2014	IAM(Integrated Audio Module)		V	V		V																											
V Series(WAGONS)	V60	2014	CCM(Climate control module)		V	V	V	V																											
V Series(WAGONS)	V60	2014	AUD(AUdio Module)		V			V																											
V Series(WAGONS)	V60	2014	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V60	2013	System Search																																
V Series(WAGONS)	V60	2013	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V60	2013	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V60	2013	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V60	2013	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V60	2013	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V60	2013	PBM(Park Brake Module)		V	V		V																											
V Series(WAGONS)	V60	2013	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V60	2013	PSCM(Power Steering Control Module)		V	V		V																											
V Series(WAGONS)	V60	2013	FSM(Forward Sensing Module)		V	V		V																											
V Series(WAGONS)	V60	2013	CVM(Closing Velocity Module)		V	V		V																											
V Series(WAGONS)	V60	2013	DIM(Driver Information Module)		V	V		V													V								V						
V Series(WAGONS)	V60	2013	SUM(SUspension Module)		V	V	V	V																											
V Series(WAGONS)	V60	2013	PAM(Parking Assistance Module)		V	V		V																											
V Series(WAGONS)	V60	2013	CEM(Central Electrical Module)		V	V	V	V																									V		
V Series(WAGONS)	V60	2013	ICM(Infotainment Control Module)		V	V		V																											
V Series(WAGONS)	V60	2013	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V60	2013	IAM(Integrated Audio Module)		V	V		V																											
V Series(WAGONS)	V60	2013	CCM(Climate control module)		V	V	V	V																											
V Series(WAGONS)	V60	2013	AUD(AUdio Module)		V			V																											
V Series(WAGONS)	V60	2013	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V60	2012	System Search																																
V Series(WAGONS)	V60	2012	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V60	2012	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V60	2012	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V60	2012	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V60	2012	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V60	2012	PBM(Park Brake Module)		V	V		V																											
V Series(WAGONS)	V60	2012	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V60	2012	PSCM(Power Steering Control Module)		V	V		V																											
V Series(WAGONS)	V60	2012	FSM(Forward Sensing Module)		V	V		V																											
V Series(WAGONS)	V60	2012	CVM(Closing Velocity Module)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
V Series(WAGONS)	V60	2012	DIM(Driver Information Module)		V	V		V													V									V					
V Series(WAGONS)	V60	2012	SUM(SUspension Module)		V	V	V	V																											
V Series(WAGONS)	V60	2012	PAM(Parking Assistance Module)		V	V		V																											
V Series(WAGONS)	V60	2012	CEM(Central Electrical Module)		V	V	V	V																									V		
V Series(WAGONS)	V60	2012	ICM(Infotainment Control Module)		V	V		V																											
V Series(WAGONS)	V60	2012	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V60	2012	IAM(Integrated Audio Module)		V	V		V																											
V Series(WAGONS)	V60	2012	CCM(Climate control module)		V	V	V	V																											
V Series(WAGONS)	V60	2012	AUD(AUdio Module)		V			V																											
V Series(WAGONS)	V60	2012	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V60	2011	System Search																																
V Series(WAGONS)	V60	2011	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V60	2011	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V60	2011	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V60	2011	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V60	2011	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V60	2011	PBM(Park Brake Module)		V	V		V																											
V Series(WAGONS)	V60	2011	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V60	2011	PSCM(Power Steering Control Module)		V	V		V																											
V Series(WAGONS)	V60	2011	FSM(Forward Sensing Module)		V	V		V																											
V Series(WAGONS)	V60	2011	CVM(Closing Velocity Module)		V	V		V																											
V Series(WAGONS)	V60	2011	DIM(Driver Information Module)		V	V		V													V									V					
V Series(WAGONS)	V60	2011	SUM(SUspension Module)		V	V	V	V																											
V Series(WAGONS)	V60	2011	PAM(Parking Assistance Module)		V	V		V																											
V Series(WAGONS)	V60	2011	CEM(Central Electrical Module)		V	V	V	V																									V		
V Series(WAGONS)	V60	2011	ICM(Infotainment Control Module)		V	V		V																											
V Series(WAGONS)	V60	2011	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V60	2011	IAM(Integrated Audio Module)		V	V		V																											
V Series(WAGONS)	V60	2011	CCM(Climate control module)		V	V	V	V																											
V Series(WAGONS)	V60	2011	AUD(AUdio Module)		V			V																											
V Series(WAGONS)	V60	2011	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V60	2010	System Search																																
V Series(WAGONS)	V60	2010	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V60	2010	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
V Series(WAGONS)	V60	2010	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
V Series(WAGONS)	V60	2010	SAS(Steering Angle Sensor module)		V	V		V																											
V Series(WAGONS)	V60	2010	BCM(Brake Control Module)		V	V	V	V																											
V Series(WAGONS)	V60	2010	PBM(Park Brake Module)		V	V		V																											
V Series(WAGONS)	V60	2010	SRS(Supplemental Restraint System)		V	V		V																											
V Series(WAGONS)	V60	2010	PSCM(Power Steering Control Module)		V	V		V																											
V Series(WAGONS)	V60	2010	FSM(Forward Sensing Module)		V	V		V																											
V Series(WAGONS)	V60	2010	CVM(Closing Velocity Module)		V	V		V																											
V Series(WAGONS)	V60	2010	DIM(Driver Information Module)		V	V		V													V									V					
V Series(WAGONS)	V60	2010	SUM(SUspension Module)		V	V	V	V																											
V Series(WAGONS)	V60	2010	PAM(Parking Assistance Module)		V	V		V																											
V Series(WAGONS)	V60	2010	CEM(Central Electrical Module)		V	V	V	V																									V		

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
V Series(WAGONS)	V60	2010	ICM(Infotainment Control Module)		V	V		V																											
V Series(WAGONS)	V60	2010	PDM(Passenger door module)		V	V	V	V																											
V Series(WAGONS)	V60	2010	IAM(Integrated Audio Module)		V	V		V																											
V Series(WAGONS)	V60	2010	CCM(Climate control module)		V	V	V	V																											
V Series(WAGONS)	V60	2010	AUD(AUdio Module)		V			V																											
V Series(WAGONS)	V60	2010	DDM(Driver Door Module)		V	V	V	V																											
V Series(WAGONS)	V70	2004~2007	System Search																																
V Series(WAGONS)	V70	2004~2007	ECM(Engine Control Module)		V			V																									V	V
V Series(WAGONS)	V70	2004~2007	TCM(Transmission Control Module)		V			V																											
V Series(WAGONS)	V70	2004~2007	ABS(Anti-Lock Brake System)		V			V																											
V Series(WAGONS)	V70	2004~2007	SRS(Supplemental Restraint System)		V			V																											
V Series(WAGONS)	V70	2004~2007	CEM(Central Electrical Module)		V			V																											
V Series(WAGONS)	V70	2004~2007	DIM(Driver Information Module)		V			V																											
V Series(WAGONS)	V70	2004~2007	DDM(Driver Door Module)		V			V																											
V Series(WAGONS)	V70	2004~2007	PDM(Passenger Door Module)		V			V																											
V Series(WAGONS)	V70	2004~2007	PSM(Power Seat Module)		V			V																											
V Series(WAGONS)	V70	2004~2007	CCM(Climate Control Module)		V			V																											
V Series(WAGONS)	V70	2004~2007	SAS(Steering Wheel Angle Sensor Module)		V			V																											
V Series(WAGONS)	V70	2004~2007	UEM(Up Electrical Module)		V			V																											
V Series(WAGONS)	V70	2004~2007	REM(Rear Electrical Module)		V			V																											
V Series(WAGONS)	V70	2004~2007	AUM(Audio Module)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	System Search																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	TCM(Transmission Control Module)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	ABS(Anti-Lock Brake System)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	SRS(Supplemental Restraint System)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	CEM(Central Electrical Module)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	DIM(Driver Information Module)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	DDM(Driver Door Module)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	PDM(Passenger Door Module)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	PSM(Power Seat Module)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	CCM(Climate Control Module)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	SWM(Steering Wheel Module)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	UEM(Up Electrical Module)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	REM(Rear Electrical Module)		V			V																											
V Series(WAGONS)	V70	2000(New Model) ~ 2004	AUM(Audio Module)		V			V																											
V Series(WAGONS)	V70	1999~2000	System Search																																
V Series(WAGONS)	V70	1999~2000	ECM(Engine Control Module)		V			V																											
V Series(WAGONS)	V70	1999~2000	TCM(Transmission Control Module)		V			V																											
V Series(WAGONS)	V70	1999~2000	ABS(Anti-Lock Brake System)		V			V																											
V Series(WAGONS)	V70	1999~2000	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	Maintenance	0	BCM(Brake control module) Service function						V	V	V	V	V	V																					
XC Series(CROSSOVERS)	Maintenance	0	PBM(Parking brake module) Service function			V									V	V	V	V	V																
XC Series(CROSSOVERS)	Maintenance	0	Service Reminder Reset		V			V												V	V														
XC Series(CROSSOVERS)	Maintenance	0	Technical Information																			V	V												
XC Series(CROSSOVERS)	V70XC	2007	System Search																																

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	V70XC	2007	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	SAS(Steering Wheel Angle Sensor Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2007	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	System Search																																
XC Series(CROSSOVERS)	V70XC	2006	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	SAS(Steering Wheel Angle Sensor Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2006	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	System Search																																
XC Series(CROSSOVERS)	V70XC	2005	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	SAS(Steering Wheel Angle Sensor Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2005	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	System Search																																
XC Series(CROSSOVERS)	V70XC	2004	ECM(Engine Control Module)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	V70XC	2004	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	SWM(Steering Wheel Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2004	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	System Search																																
XC Series(CROSSOVERS)	V70XC	2003	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	SWM(Steering Wheel Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2003	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	System Search																																
XC Series(CROSSOVERS)	V70XC	2002	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	SWM(Steering Wheel Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2002	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	System Search																																
XC Series(CROSSOVERS)	V70XC	2001	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	TCM(Transmission Control Module)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	V70XC	2001	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	SWM(Steering Wheel Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2001	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	System Search																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	SWM(Steering Wheel Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000(New Model)	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000	System Search																																
XC Series(CROSSOVERS)	V70XC	2000	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	2000	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	V70XC	1999	System Search																																
XC Series(CROSSOVERS)	V70XC	1999	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	1999	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	V70XC	1999	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC60	2015	System Search																																
XC Series(CROSSOVERS)	XC60	2015	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC60	2015	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
XC Series(CROSSOVERS)	XC60	2015	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2015	SAS(Steering Angle Sensor module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2015	BCM(Brake Control Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2015	PBM(Park Brake Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2015	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2015	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2015	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2015	CVM(Closing Velocity Module)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	XC60	2015	DIM(Driver Information Module)		V	V		V													V									V					
XC Series(CROSSOVERS)	XC60	2015	PAM(Parking Assistance Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2015	CEM(Central Electrical Module)		V	V	V	V																									V		
XC Series(CROSSOVERS)	XC60	2015	ICM(Infotainment Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2015	PDM(Passenger door module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2015	CCM(Climate control module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2015	AUD(AUdio Module)		V			V																											
XC Series(CROSSOVERS)	XC60	2015	DDM(Driver Door Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2015	PSM(Power Seat Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2015	DEM(Differential Electronic Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2015	POT(Power operated tailgate module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2015	SODR(Side Obstacle Detection control module Right)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2015	SODL(Side Obstacle Detection control module Left)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2015	RDAR(Remote Digital Audio Receiver)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2015	BPM(Bluetooth phone module)		V			V																											
XC Series(CROSSOVERS)	XC60	2014	System Search																																
XC Series(CROSSOVERS)	XC60	2014	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC60	2014	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
XC Series(CROSSOVERS)	XC60	2014	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2014	SAS(Steering Angle Sensor module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	BCM(Brake Control Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2014	PBM(Park Brake Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	CVM(Closing Velocity Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	DIM(Driver Information Module)		V	V		V													V									V					
XC Series(CROSSOVERS)	XC60	2014	PAM(Parking Assistance Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	CEM(Central Electrical Module)		V	V	V	V																									V		
XC Series(CROSSOVERS)	XC60	2014	ICM(Infotainment Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	PDM(Passenger door module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2014	CCM(Climate control module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2014	AUD(AUdio Module)		V			V																											
XC Series(CROSSOVERS)	XC60	2014	DDM(Driver Door Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2014	PSM(Power Seat Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2014	DEM(Differential Electronic Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	POT(Power operated tailgate module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	SODR(Side Obstacle Detection control module Right)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	SODL(Side Obstacle Detection control module Left)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	RDAR(Remote Digital Audio Receiver)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2014	BPM(Bluetooth phone module)		V			V																											
XC Series(CROSSOVERS)	XC60	2013	System Search																																
XC Series(CROSSOVERS)	XC60	2013	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC60	2013	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
XC Series(CROSSOVERS)	XC60	2013	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2013	SAS(Steering Angle Sensor module)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	XC60	2013	BCM(Brake Control Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2013	PBM(Park Brake Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2013	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2013	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2013	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2013	CVM(Closing Velocity Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2013	DIM(Driver Information Module)		V	V		V													V									V					
XC Series(CROSSOVERS)	XC60	2013	PAM(Parking Assistance Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2013	CEM(Central Electrical Module)		V	V	V	V																									V		
XC Series(CROSSOVERS)	XC60	2013	ICM(Infotainment Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2013	PDM(Passenger door module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2013	CCM(Climate control module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2013	AUD(AUdio Module)		V			V																											
XC Series(CROSSOVERS)	XC60	2013	DDM(Driver Door Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2013	PSM(Power Seat Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2013	DEM(Differential Electronic Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2013	POT(Power operated tailgate module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2013	SODR(Side Obstacle Detection control module Right)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2013	SODL(Side Obstacle Detection control module Left)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2013	RDAR(Remote Digital Audio Receiver)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2013	BPM(Bluetooth phone module)		V			V																											
XC Series(CROSSOVERS)	XC60	2012	System Search																																
XC Series(CROSSOVERS)	XC60	2012	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC60	2012	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
XC Series(CROSSOVERS)	XC60	2012	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2012	SAS(Steering Angle Sensor module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2012	BCM(Brake Control Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2012	PBM(Park Brake Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2012	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2012	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2012	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2012	CVM(Closing Velocity Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2012	DIM(Driver Information Module)		V	V		V													V									V					
XC Series(CROSSOVERS)	XC60	2012	PAM(Parking Assistance Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2012	CEM(Central Electrical Module)		V	V	V	V																									V		
XC Series(CROSSOVERS)	XC60	2012	ICM(Infotainment Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2012	PDM(Passenger door module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2012	CCM(Climate control module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2012	AUD(AUdio Module)		V			V																											
XC Series(CROSSOVERS)	XC60	2012	DDM(Driver Door Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2012	PSM(Power Seat Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2012	DEM(Differential Electronic Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2012	POT(Power operated tailgate module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2012	SODR(Side Obstacle Detection control module Right)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2012	SODL(Side Obstacle Detection control module Left)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2012	RDAR(Remote Digital Audio Receiver)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	XC60	2012	BPM(Bluetooth phone module)		V			V																											
XC Series(CROSSOVERS)	XC60	2011	System Search																																
XC Series(CROSSOVERS)	XC60	2011	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC60	2011	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
XC Series(CROSSOVERS)	XC60	2011	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2011	SAS(Steering Angle Sensor module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	BCM(Brake Control Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2011	PBM(Park Brake Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	CVM(Closing Velocity Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	DIM(Driver Information Module)		V	V		V													V									V					
XC Series(CROSSOVERS)	XC60	2011	PAM(Parking Assistance Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	CEM(Central Electrical Module)		V	V	V	V																									V		
XC Series(CROSSOVERS)	XC60	2011	ICM(Infotainment Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	PDM(Passenger door module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2011	CCM(Climate control module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2011	AUD(AUdio Module)		V			V																											
XC Series(CROSSOVERS)	XC60	2011	DDM(Driver Door Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2011	PSM(Power Seat Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2011	DEM(Differential Electronic Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	POT(Power operated tailgate module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	SODR(Side Obstacle Detection control module Right)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	SODL(Side Obstacle Detection control module Left)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	RDAR(Remote Digital Audio Receiver)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2011	BPM(Bluetooth phone module)		V			V																											
XC Series(CROSSOVERS)	XC60	2010	System Search																																
XC Series(CROSSOVERS)	XC60	2010	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC60	2010	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
XC Series(CROSSOVERS)	XC60	2010	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2010	SAS(Steering Angle Sensor module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	BCM(Brake Control Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2010	PBM(Park Brake Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	CVM(Closing Velocity Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	DIM(Driver Information Module)		V	V		V													V									V					
XC Series(CROSSOVERS)	XC60	2010	PAM(Parking Assistance Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	CEM(Central Electrical Module)		V	V	V	V																									V		
XC Series(CROSSOVERS)	XC60	2010	ICM(Infotainment Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	PDM(Passenger door module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2010	CCM(Climate control module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2010	AUD(AUdio Module)		V			V																											
XC Series(CROSSOVERS)	XC60	2010	DDM(Driver Door Module)		V	V	V	V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	XC60	2010	PSM(Power Seat Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC60	2010	DEM(Differential Electronic Module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	POT(Power operated tailgate module)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	SODR(Side Obstacle Detection control module Right)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	SODL(Side Obstacle Detection control module Left)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	RDAR(Remote Digital Audio Receiver)		V	V		V																											
XC Series(CROSSOVERS)	XC60	2010	BPM(Bluetooth phone module)		V			V																											
XC Series(CROSSOVERS)	XC70	2015	System Search																																
XC Series(CROSSOVERS)	XC70	2015	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2015	TCM(Transmission Control Module)	TF-80SC	V	V	V	V															V	V	V	V									
XC Series(CROSSOVERS)	XC70	2015	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2015	SAS(Steering Angle Sensor module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	BCM(Brake Control Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2015	PBM(Park Brake Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	CVM(Closing Velocity Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	DIM(Driver Information Module)		V	V		V													V									V					
XC Series(CROSSOVERS)	XC70	2015	PAM(Parking Assistance Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	CEM(Central Electrical Module)		V	V	V	V																								V			
XC Series(CROSSOVERS)	XC70	2015	ICM(Infotainment Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	PDM(Passenger door module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2015	CCM(Climate control module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2015	AUD(AUdio Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2015	DDM(Driver Door Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2015	PSM(Power Seat Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2015	DEM(Differential Electronic Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	POT(Power operated tailgate module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	SODR(Side Obstacle Detection control module Right)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	SODL(Side Obstacle Detection control module Left)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	RDAR(Remote Digital Audio Receiver)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2015	BPM(Bluetooth phone module)		V			V																											
XC Series(CROSSOVERS)	XC70	2014	System Search																																
XC Series(CROSSOVERS)	XC70	2014	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2014	TCM(Transmission Control Module)	TF-80SC	V	V	V	V															V	V	V	V									
XC Series(CROSSOVERS)	XC70	2014	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2014	SAS(Steering Angle Sensor module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2014	BCM(Brake Control Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2014	PBM(Park Brake Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2014	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2014	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2014	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2014	CVM(Closing Velocity Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2014	DIM(Driver Information Module)		V	V		V													V									V					
XC Series(CROSSOVERS)	XC70	2014	PAM(Parking Assistance Module)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	XC70	2014	CEM(Central Electrical Module)		V	V	V	V																										V		
XC Series(CROSSOVERS)	XC70	2014	ICM(Infotainment Control Module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2014	PDM(Passenger door module)		V	V	V	V																												
XC Series(CROSSOVERS)	XC70	2014	CCM(Climate control module)		V	V	V	V																												
XC Series(CROSSOVERS)	XC70	2014	AUD(AUdio Module)		V			V																												
XC Series(CROSSOVERS)	XC70	2014	DDM(Driver Door Module)		V	V	V	V																												
XC Series(CROSSOVERS)	XC70	2014	PSM(Power Seat Module)		V	V	V	V																												
XC Series(CROSSOVERS)	XC70	2014	DEM(Differential Electronic Module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2014	POT(Power operated tailgate module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2014	SODR(Side Obstacle Detection control module Right)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2014	SODL(Side Obstacle Detection control module Left)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2014	RDAR(Remote Digital Audio Receiver)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2014	BPM(Bluetooth phone module)		V			V																												
XC Series(CROSSOVERS)	XC70	2013	System Search																																	
XC Series(CROSSOVERS)	XC70	2013	ECM(Engine Control Module)		V			V																												
XC Series(CROSSOVERS)	XC70	2013	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V									
XC Series(CROSSOVERS)	XC70	2013	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																												
XC Series(CROSSOVERS)	XC70	2013	SAS(Steering Angle Sensor module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	BCM(Brake Control Module)		V	V	V	V																												
XC Series(CROSSOVERS)	XC70	2013	PBM(Park Brake Module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	SRS(Supplemental Restraint System)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	PSCM(Power Steering Control Module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	FSM(Forward Sensing Module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	CVM(Closing Velocity Module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	DIM(Driver Information Module)		V	V		V													V									V						
XC Series(CROSSOVERS)	XC70	2013	PAM(Parking Assistance Module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	CEM(Central Electrical Module)		V	V	V	V																										V		
XC Series(CROSSOVERS)	XC70	2013	ICM(Infotainment Control Module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	PDM(Passenger door module)		V	V	V	V																												
XC Series(CROSSOVERS)	XC70	2013	CCM(Climate control module)		V	V	V	V																												
XC Series(CROSSOVERS)	XC70	2013	AUD(AUdio Module)		V			V																												
XC Series(CROSSOVERS)	XC70	2013	DDM(Driver Door Module)		V	V	V	V																												
XC Series(CROSSOVERS)	XC70	2013	PSM(Power Seat Module)		V	V	V	V																												
XC Series(CROSSOVERS)	XC70	2013	DEM(Differential Electronic Module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	POT(Power operated tailgate module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	SODR(Side Obstacle Detection control module Right)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	SODL(Side Obstacle Detection control module Left)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	RDAR(Remote Digital Audio Receiver)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2013	BPM(Bluetooth phone module)		V			V																												
XC Series(CROSSOVERS)	XC70	2012	System Search																																	
XC Series(CROSSOVERS)	XC70	2012	ECM(Engine Control Module)		V			V																												
XC Series(CROSSOVERS)	XC70	2012	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V									
XC Series(CROSSOVERS)	XC70	2012	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																												
XC Series(CROSSOVERS)	XC70	2012	SAS(Steering Angle Sensor module)		V	V		V																												
XC Series(CROSSOVERS)	XC70	2012	BCM(Brake Control Module)		V	V	V	V																												
XC Series(CROSSOVERS)	XC70	2012	PBM(Park Brake Module)		V	V		V																												

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the 'Transmission fluid change' counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	XC70	2012	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2012	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2012	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2012	CVM(Closing Velocity Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2012	DIM(Driver Information Module)		V	V		V													V								V						
XC Series(CROSSOVERS)	XC70	2012	PAM(Parking Assistance Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2012	CEM(Central Electrical Module)		V	V	V	V																									V		
XC Series(CROSSOVERS)	XC70	2012	ICM(Infotainment Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2012	PDM(Passenger door module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2012	CCM(Climate control module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2012	AUD(AUdio Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2012	DDM(Driver Door Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2012	PSM(Power Seat Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2012	DEM(Differential Electronic Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2012	POT(Power operated tailgate module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2012	SODR(Side Obstacle Detection control module Right)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2012	SODL(Side Obstacle Detection control module Left)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2012	RDAR(Remote Digital Audio Receiver)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2012	BPM(Bluetooth phone module)		V			V																											
XC Series(CROSSOVERS)	XC70	2011	System Search																																
XC Series(CROSSOVERS)	XC70	2011	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2011	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
XC Series(CROSSOVERS)	XC70	2011	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2011	SAS(Steering Angle Sensor module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	BCM(Brake Control Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2011	PBM(Park Brake Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	CVM(Closing Velocity Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	DIM(Driver Information Module)		V	V		V													V								V						
XC Series(CROSSOVERS)	XC70	2011	PAM(Parking Assistance Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	CEM(Central Electrical Module)		V	V	V	V																									V		
XC Series(CROSSOVERS)	XC70	2011	ICM(Infotainment Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	PDM(Passenger door module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2011	CCM(Climate control module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2011	AUD(AUdio Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2011	DDM(Driver Door Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2011	PSM(Power Seat Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2011	DEM(Differential Electronic Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	POT(Power operated tailgate module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	SODR(Side Obstacle Detection control module Right)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	SODL(Side Obstacle Detection control module Left)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	RDAR(Remote Digital Audio Receiver)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2011	BPM(Bluetooth phone module)		V			V																											
XC Series(CROSSOVERS)	XC70	2010	System Search																																

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	XC70	2010	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2010	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
XC Series(CROSSOVERS)	XC70	2010	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2010	SAS(Steering Angle Sensor module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	BCM(Brake Control Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2010	PBM(Park Brake Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	CVM(Closing Velocity Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	DIM(Driver Information Module)		V	V		V													V									V					
XC Series(CROSSOVERS)	XC70	2010	PAM(Parking Assistance Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	CEM(Central Electrical Module)		V	V	V	V																									V		
XC Series(CROSSOVERS)	XC70	2010	ICM(Infotainment Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	PDM(Passenger door module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2010	CCM(Climate control module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2010	AUD(AUdio Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2010	DDM(Driver Door Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2010	PSM(Power Seat Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2010	DEM(Differential Electronic Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	POT(Power operated tailgate module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	SODR(Side Obstacle Detection control module Right)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	SODL(Side Obstacle Detection control module Left)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	RDAR(Remote Digital Audio Receiver)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2010	BPM(Bluetooth phone module)		V			V																											
XC Series(CROSSOVERS)	XC70	2009	System Search																																
XC Series(CROSSOVERS)	XC70	2009	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2009	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
XC Series(CROSSOVERS)	XC70	2009	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2009	SAS(Steering Angle Sensor module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2009	BCM(Brake Control Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2009	PBM(Park Brake Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2009	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2009	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2009	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2009	CVM(Closing Velocity Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2009	DIM(Driver Information Module)		V	V		V													V									V					
XC Series(CROSSOVERS)	XC70	2009	PAM(Parking Assistance Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2009	CEM(Central Electrical Module)		V	V	V	V																									V		
XC Series(CROSSOVERS)	XC70	2009	ICM(Infotainment Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2009	PDM(Passenger door module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2009	CCM(Climate control module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2009	AUD(AUdio Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2009	DDM(Driver Door Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2009	PSM(Power Seat Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2009	DEM(Differential Electronic Module)		V	V		V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	XC70	2009	POT(Power operated tailgate module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2009	SODR(Side Obstacle Detection control module Right)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2009	SODL(Side Obstacle Detection control module Left)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2009	RDAR(Remote Digital Audio Receiver)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2009	BPM(Bluetooth phone module)		V			V																											
XC Series(CROSSOVERS)	XC70	2008	System Search																																
XC Series(CROSSOVERS)	XC70	2008	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2008	TCM(Transmission Control Module)	TF-80SC	V	V	V	V																V	V	V	V								
XC Series(CROSSOVERS)	XC70	2008	TCM(Transmission Control Module)	TG-81SC	V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2008	SAS(Steering Angle Sensor module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	BCM(Brake Control Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2008	PBM(Park Brake Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	SRS(Supplemental Restraint System)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	PSCM(Power Steering Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	FSM(Forward Sensing Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	CVM(Closing Velocity Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	DIM(Driver Information Module)		V	V		V													V									V					
XC Series(CROSSOVERS)	XC70	2008	PAM(Parking Assistance Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	CEM(Central Electrical Module)		V	V	V	V																									V		
XC Series(CROSSOVERS)	XC70	2008	ICM(Infotainment Control Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	PDM(Passenger door module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2008	CCM(Climate control module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2008	AUD(AUdio Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2008	DDM(Driver Door Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2008	PSM(Power Seat Module)		V	V	V	V																											
XC Series(CROSSOVERS)	XC70	2008	DEM(Differential Electronic Module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	POT(Power operated tailgate module)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	SODR(Side Obstacle Detection control module Right)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	SODL(Side Obstacle Detection control module Left)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	RDAR(Remote Digital Audio Receiver)		V	V		V																											
XC Series(CROSSOVERS)	XC70	2008	BPM(Bluetooth phone module)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	System Search																																
XC Series(CROSSOVERS)	XC70	2007	ECM(Engine Control Module)		V			V																									V	V
XC Series(CROSSOVERS)	XC70	2007	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	SAS(Steering Wheel Angle Sensor Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2007	AUM(Audio Module)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	XC70	2006	System Search																																
XC Series(CROSSOVERS)	XC70	2006	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	SAS(Steering Wheel Angle Sensor Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2006	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	System Search																																
XC Series(CROSSOVERS)	XC70	2005	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	SAS(Steering Wheel Angle Sensor Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2005	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	System Search																																
XC Series(CROSSOVERS)	XC70	2004	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	SWM(Steering Wheel Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2004	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	System Search																																

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	XC70	2003	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	SWM(Steering Wheel Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2003	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	System Search																																
XC Series(CROSSOVERS)	XC70	2002	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	SWM(Steering Wheel Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2002	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	System Search																																
XC Series(CROSSOVERS)	XC70	2001	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	SWM(Steering Wheel Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC70	2001	AUM(Audio Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2007	System Search																																
XC Series(CROSSOVERS)	XC90	2007	ECM(Engine Control Module)		V			V																									V	V

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	XC90	2007	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2007	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC90	2007	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	XC90	2007	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2007	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2007	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2007	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2007	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2007	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2007	SAS(Steering Wheel Angle Sensor Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2007	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2007	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	System Search																																
XC Series(CROSSOVERS)	XC90	2006	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	SAS(Steering Wheel Angle Sensor Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2006	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	System Search																																
XC Series(CROSSOVERS)	XC90	2005	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	SAS(Steering Wheel Angle Sensor Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2005	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2004	System Search																																
XC Series(CROSSOVERS)	XC90	2004	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2004	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2004	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC90	2004	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	XC90	2004	CEM(Central Electrical Module)		V			V																											

Series	Vehicle	Year	System 1	System 2	DTC Analysis	Data Analysis	Actuator	ECU Information Display	AWD-Steering angle calibration	AWD-Lateral acceleration sensor calibration	AWD-Longitudinal acceleration sensor calibration	AWD-Yaw late sensor calibration	AWD-Pressure sensor calibration	2WD-Lateral acceleration sensor calibration	Service information	Apply parking brake	Release parking brake	Active service mode	Deactive service mode	Service Reminder Reset	Resetting the service reminder indicator (SRI)	Abbreviations	Service Reminder Reset(MANUAL)	Resetting adaptation	Resetting the "Transmission fluid change" counter	Activating gear indication	Control module adaptation	Testing all indicators and lamps in the driver information module (DIM)	Display of DSTC message	Programming the driver information module (DIM)	Programming the gear shift indicator	Resetting the service reminder indicator(SRI)	Resetting the information when replacing the battery	Adaptation of throttle module	Adaptation of swivel channel throttle
XC Series(CROSSOVERS)	XC90	2004	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2004	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2004	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2004	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2004	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2004	SWM(Steering Wheel Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2004	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2004	REM(Rear Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	System Search																																
XC Series(CROSSOVERS)	XC90	2003	ECM(Engine Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	TCM(Transmission Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	ABS(Anti-Lock Brake System)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	SRS(Supplemental Restraint System)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	CEM(Central Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	DIM(Driver Information Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	DDM(Driver Door Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	PDM(Passenger Door Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	PSM(Power Seat Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	CCM(Climate Control Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	SWM(Steering Wheel Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	UEM(Up Electrical Module)		V			V																											
XC Series(CROSSOVERS)	XC90	2003	REM(Rear Electrical Module)		V			V																											

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
C Series(COUPES)	Maintenance		BCM(Brake control module) Service function																																
C Series(COUPES)	Maintenance		PBM(Parking brake module) Service function																																
C Series(COUPES)	Maintenance		Service Reminder Reset																																
C Series(COUPES)	Maintenance		Technical Information																																
C Series(COUPES)	C30	2012	System Search																																
C Series(COUPES)	C30	2012	ECM(Engine Control Module)																																
C Series(COUPES)	C30	2012	TCM(Transmission Control Module)	TF-80SC																															
C Series(COUPES)	C30	2012	TCM(Transmission Control Module)	TG-81SC																															
C Series(COUPES)	C30	2012	SAS(Steering Angle Sensor module)																																
C Series(COUPES)	C30	2012	BCM(Brake Control Module)																																
C Series(COUPES)	C30	2012	SRS(Supplemental Restraint System)																																
C Series(COUPES)	C30	2012	DIM(Driver Information Module)																																
C Series(COUPES)	C30	2012	CEM(Central Electrical Module)																																
C Series(COUPES)	C30	2012	PDM(Passenger door module)																																
C Series(COUPES)	C30	2012	DDM(Driver door module)																																
C Series(COUPES)	C30	2012	EPS(Electrical power steering module)																																
C Series(COUPES)	C30	2012	HCM(Headlamp control module)																																
C Series(COUPES)	C30	2011	System Search																																
C Series(COUPES)	C30	2011	ECM(Engine Control Module)																																
C Series(COUPES)	C30	2011	TCM(Transmission Control Module)	TF-80SC																															
C Series(COUPES)	C30	2011	TCM(Transmission Control Module)	TG-81SC																															
C Series(COUPES)	C30	2011	SAS(Steering Angle Sensor module)																																
C Series(COUPES)	C30	2011	BCM(Brake Control Module)																																
C Series(COUPES)	C30	2011	SRS(Supplemental Restraint System)																																
C Series(COUPES)	C30	2011	DIM(Driver Information Module)																																
C Series(COUPES)	C30	2011	CEM(Central Electrical Module)																																
C Series(COUPES)	C30	2011	PDM(Passenger door module)																																
C Series(COUPES)	C30	2011	DDM(Driver door module)																																
C Series(COUPES)	C30	2011	EPS(Electrical power steering module)																																
C Series(COUPES)	C30	2011	HCM(Headlamp control module)																																
C Series(COUPES)	C30	2010	System Search																																
C Series(COUPES)	C30	2010	ECM(Engine Control Module)																																
C Series(COUPES)	C30	2010	TCM(Transmission Control Module)	TF-80SC																															
C Series(COUPES)	C30	2010	TCM(Transmission Control Module)	TG-81SC																															
C Series(COUPES)	C30	2010	ABS(Anti-Lock Brake System)																																
C Series(COUPES)	C30	2010	SAS(Steering Angle Sensor module)																																
C Series(COUPES)	C30	2010	BCM(Brake Control Module)																																
C Series(COUPES)	C30	2010	SRS(Supplemental Restraint System)																																
C Series(COUPES)	C30	2010	DIM(Driver Information Module)																																
C Series(COUPES)	C30	2010	CEM(Central Electrical Module)																																
C Series(COUPES)	C30	2010	PDM(Passenger door module)																																
C Series(COUPES)	C30	2010	DDM(Driver door module)																																
C Series(COUPES)	C30	2010	PSM(Power Seat Module)																																
C Series(COUPES)	C30	2010	CCM(Climate Control Module)																																
C Series(COUPES)	C30	2010	EPS(Electrical power steering module)																																
C Series(COUPES)	C30	2010	SWM(Steering Wheel Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
C Series(COUPES)	C30	2010	HCM(Headlamp control module)																																
C Series(COUPES)	C30	2009	System Search																																
C Series(COUPES)	C30	2009	ECM(Engine Control Module)																																
C Series(COUPES)	C30	2009	TCM(Transmission Control Module)	TF-80SC																															
C Series(COUPES)	C30	2009	TCM(Transmission Control Module)	TG-81SC																															
C Series(COUPES)	C30	2009	ABS(Anti-Lock Brake System)																																
C Series(COUPES)	C30	2009	SAS(Steering Angle Sensor module)																																
C Series(COUPES)	C30	2009	BCM(Brake Control Module)																																
C Series(COUPES)	C30	2009	SRS(Supplemental Restraint System)																																
C Series(COUPES)	C30	2009	DIM(Driver Information Module)																																
C Series(COUPES)	C30	2009	CEM(Central Electrical Module)																																
C Series(COUPES)	C30	2009	PDM(Passenger door module)																																
C Series(COUPES)	C30	2009	DDM(Driver door module)																																
C Series(COUPES)	C30	2009	PSM(Power Seat Module)																																
C Series(COUPES)	C30	2009	CCM(Climate Control Module)																																
C Series(COUPES)	C30	2009	EPS(Electrical power steering module)																																
C Series(COUPES)	C30	2009	SWM(Steering Wheel Module)																																
C Series(COUPES)	C30	2009	HCM(Headlamp control module)																																
C Series(COUPES)	C30	2008	System Search																																
C Series(COUPES)	C30	2008	ECM(Engine Control Module)		V	V	V	V	V	V																									
C Series(COUPES)	C30	2008	TCM(Transmission Control Module)	TF-80SC							V	V	V																						
C Series(COUPES)	C30	2008	TCM(Transmission Control Module)	AW55-50 - 51 SN							V	V	V	V																					
C Series(COUPES)	C30	2008	ABS(Anti-Lock Brake System)												V																				
C Series(COUPES)	C30	2008	SRS(Supplemental Restraint System)																																
C Series(COUPES)	C30	2008	DIM(Driver Information Module)																																
C Series(COUPES)	C30	2008	PAM(Parking Assistance Module)																																
C Series(COUPES)	C30	2008	CEM(Central Electrical Module)													V	V	V	V																
C Series(COUPES)	C30	2008	ICM(Infotainment Control Module)																	V	V	V													
C Series(COUPES)	C30	2008	PDM(Passenger Door Module)																																
C Series(COUPES)	C30	2008	IAM(Integrated Audio Module)																																
C Series(COUPES)	C30	2008	CCM(Climate Control Module)																																
C Series(COUPES)	C30	2008	AUD(AUdio Module)																																
C Series(COUPES)	C30	2008	DDM(Driver Door Module)																																
C Series(COUPES)	C30	2008	PSM(Power Seat Module)																																
C Series(COUPES)	C30	2008	SWM(Steering Wheel Module)																																
C Series(COUPES)	C30	2007	System Search																																
C Series(COUPES)	C30	2007	ECM(Engine Control Module)		V	V	V	V	V	V																									
C Series(COUPES)	C30	2007	TCM(Transmission Control Module)																																
C Series(COUPES)	C30	2007	ABS(Anti-Lock Brake System)																																
C Series(COUPES)	C30	2007	SRS(Supplemental Restraint System)																																
C Series(COUPES)	C30	2007	CEM(Central Electrical Module)																																
C Series(COUPES)	C30	2007	DIM(Driver Information Module)																																
C Series(COUPES)	C30	2007	DDM(Driver Door Module)																																
C Series(COUPES)	C30	2007	PDM(Passenger Door Module)																																
C Series(COUPES)	C30	2007	PSM(Power Seat Module)																																
C Series(COUPES)	C30	2007	CCM(Climate Control Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
C Series(COUPES)	C30	2007	SWM(Steering Wheel Module)																																
C Series(COUPES)	C70	C70 Convertible	2007	System Search																															
C Series(COUPES)	C70	C70 Convertible	2007	ECM(Engine Control Module)	V	V	V	V	V	V																									
C Series(COUPES)	C70	C70 Convertible	2007	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2007	ABS(Anti-Lock Brake System)																															
C Series(COUPES)	C70	C70 Convertible	2007	SRS(Supplemental Restraint System)																															
C Series(COUPES)	C70	C70 Convertible	2007	CEM(Central Electrical Module)																															
C Series(COUPES)	C70	C70 Convertible	2007	DIM(Driver Information Module)																															
C Series(COUPES)	C70	C70 Convertible	2007	DDM(Driver Door Module)																															
C Series(COUPES)	C70	C70 Convertible	2007	PDM(Passenger Door Module)																															
C Series(COUPES)	C70	C70 Convertible	2007	PSM(Power Seat Module)																															
C Series(COUPES)	C70	C70 Convertible	2007	CCM(Climate Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2007	SWM(Steering Wheel Module)																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	System Search																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	ECM(Engine Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	ABS(Anti-Lock Brake System)																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	SRS(Supplemental Restraint System)																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	CEM(Central Electrical Module)																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	DIM(Driver Information Module)																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	DDM(Driver Door Module)																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	PDM(Passenger Door Module)																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	PSM(Power Seat Module)																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	CCM(Climate Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	SWM(Steering Wheel Module)																															
C Series(COUPES)	C70	C70 Convertible	2005	System Search																															
C Series(COUPES)	C70	C70 Convertible	2005	ECM(Engine Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2005	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2005	ABS(Anti-Lock Brake System)																															
C Series(COUPES)	C70	C70 Convertible	2004	System Search																															
C Series(COUPES)	C70	C70 Convertible	2004	ECM(Engine Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2004	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2004	ABS(Anti-Lock Brake System)																															
C Series(COUPES)	C70	C70 Convertible	2003	System Search																															
C Series(COUPES)	C70	C70 Convertible	2003	ECM(Engine Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2003	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2003	ABS(Anti-Lock Brake System)																															
C Series(COUPES)	C70	C70 Convertible	2002	System Search																															
C Series(COUPES)	C70	C70 Convertible	2002	ECM(Engine Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2002	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2002	ABS(Anti-Lock Brake System)																															
C Series(COUPES)	C70	C70 Convertible	2001	System Search																															
C Series(COUPES)	C70	C70 Convertible	2001	ECM(Engine Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2001	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2001	ABS(Anti-Lock Brake System)																															
C Series(COUPES)	C70	C70 Convertible	2000	System Search																															

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
C Series(COUPES)	C70	C70 Convertible	2000	ECM(Engine Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2000	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Convertible	2000	ABS(Anti-Lock Brake System)																															
C Series(COUPES)	C70	C70 Convertible	1999	System Search																															
C Series(COUPES)	C70	C70 Convertible	1999	ECM(Engine Control Module)																															
C Series(COUPES)	C70	C70 Convertible	1999	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Convertible	1999	ABS(Anti-Lock Brake System)																															
C Series(COUPES)	C70	C70 Coupe	2002	System Search																															
C Series(COUPES)	C70	C70 Coupe	2002	ECM(Engine Control Module)																															
C Series(COUPES)	C70	C70 Coupe	2002	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Coupe	2002	ABS(Anti-Lock Brake System)																															
C Series(COUPES)	C70	C70 Coupe	2001	System Search																															
C Series(COUPES)	C70	C70 Coupe	2001	ECM(Engine Control Module)																															
C Series(COUPES)	C70	C70 Coupe	2001	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Coupe	2001	ABS(Anti-Lock Brake System)																															
C Series(COUPES)	C70	C70 Coupe	2000	System Search																															
C Series(COUPES)	C70	C70 Coupe	2000	ECM(Engine Control Module)																															
C Series(COUPES)	C70	C70 Coupe	2000	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Coupe	2000	ABS(Anti-Lock Brake System)																															
C Series(COUPES)	C70	C70 Coupe	1999	System Search																															
C Series(COUPES)	C70	C70 Coupe	1999	ECM(Engine Control Module)																															
C Series(COUPES)	C70	C70 Coupe	1999	TCM(Transmission Control Module)																															
C Series(COUPES)	C70	C70 Coupe	1999	ABS(Anti-Lock Brake System)																															
S Series(SEDANS)	Maintenance	BCM(Brake control module) Service function																																	
S Series(SEDANS)	Maintenance	PBM(Parking brake module) Service function																																	
S Series(SEDANS)	Maintenance	Service Reminder Reset																																	
S Series(SEDANS)	Maintenance	Technical Information																																	
S Series(SEDANS)	S40	2008	System Search																																
S Series(SEDANS)	S40	2008	ECM(Engine Control Module)		V	V	V	V	V	V																									
S Series(SEDANS)	S40	2008	TCM(Transmission Control Module)																																
S Series(SEDANS)	S40	2008	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S40	2008	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S40	2008	CEM(Central Electrical Module)																																
S Series(SEDANS)	S40	2008	DIM(Driver Information Module)																																
S Series(SEDANS)	S40	2008	DDM(Driver Door Module)																																
S Series(SEDANS)	S40	2008	PDM(Passenger Door Module)																																
S Series(SEDANS)	S40	2008	PSM(Power Seat Module)																																
S Series(SEDANS)	S40	2008	CCM(Climate Control Module)																																
S Series(SEDANS)	S40	2008	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S40	2007	System Search																																
S Series(SEDANS)	S40	2007	ECM(Engine Control Module)		V	V	V	V	V	V																									
S Series(SEDANS)	S40	2007	TCM(Transmission Control Module)																																
S Series(SEDANS)	S40	2007	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S40	2007	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S40	2007	CEM(Central Electrical Module)																																
S Series(SEDANS)	S40	2007	DIM(Driver Information Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S40	2007	DDM(Driver Door Module)																																
S Series(SEDANS)	S40	2007	PDM(Passenger Door Module)																																
S Series(SEDANS)	S40	2007	PSM(Power Seat Module)																																
S Series(SEDANS)	S40	2007	CCM(Climate Control Module)																																
S Series(SEDANS)	S40	2007	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S40	2006	System Search																																
S Series(SEDANS)	S40	2006	ECM(Engine Control Module)																																
S Series(SEDANS)	S40	2006	TCM(Transmission Control Module)																																
S Series(SEDANS)	S40	2006	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S40	2006	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S40	2006	CEM(Central Electrical Module)																																
S Series(SEDANS)	S40	2006	DIM(Driver Information Module)																																
S Series(SEDANS)	S40	2006	DDM(Driver Door Module)																																
S Series(SEDANS)	S40	2006	PDM(Passenger Door Module)																																
S Series(SEDANS)	S40	2006	PSM(Power Seat Module)																																
S Series(SEDANS)	S40	2006	CCM(Climate Control Module)																																
S Series(SEDANS)	S40	2006	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S40	2005	System Search																																
S Series(SEDANS)	S40	2005	ECM(Engine Control Module)																																
S Series(SEDANS)	S40	2005	TCM(Transmission Control Module)																																
S Series(SEDANS)	S40	2005	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S40	2005	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S40	2005	CEM(Central Electrical Module)																																
S Series(SEDANS)	S40	2005	DIM(Driver Information Module)																																
S Series(SEDANS)	S40	2005	DDM(Driver Door Module)																																
S Series(SEDANS)	S40	2005	PDM(Passenger Door Module)																																
S Series(SEDANS)	S40	2005	PSM(Power Seat Module)																																
S Series(SEDANS)	S40	2005	CCM(Climate Control Module)																																
S Series(SEDANS)	S40	2005	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S40	2004(New Model)	System Search																																
S Series(SEDANS)	S40	2004(New Model)	ECM(Engine Control Module)																																
S Series(SEDANS)	S40	2004(New Model)	TCM(Transmission Control Module)																																
S Series(SEDANS)	S40	2004(New Model)	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S40	2004(New Model)	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S40	2004(New Model)	CEM(Central Electrical Module)																																
S Series(SEDANS)	S40	2004(New Model)	DIM(Driver Information Module)																																
S Series(SEDANS)	S40	2004(New Model)	DDM(Driver Door Module)																																
S Series(SEDANS)	S40	2004(New Model)	PDM(Passenger Door Module)																																
S Series(SEDANS)	S40	2004(New Model)	PSM(Power Seat Module)																																
S Series(SEDANS)	S40	2004(New Model)	CCM(Climate Control Module)																																
S Series(SEDANS)	S40	2004(New Model)	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S60	2015	System Search																																
S Series(SEDANS)	S60	2015	ECM(Engine Control Module)																																
S Series(SEDANS)	S60	2015	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S60	2015	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S60	2015	SAS(Steering Angle Sensor module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S60	2015	BCM(Brake Control Module)																																
S Series(SEDANS)	S60	2015	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S60	2015	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2015	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S60	2015	FSM(Forward Sensing Module)																					V											
S Series(SEDANS)	S60	2015	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S60	2015	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S60	2015	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S60	2015	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S60	2015	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S60	2015	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S60	2015	PHM(PHone Module)																															V	
S Series(SEDANS)	S60	2015	IAM(Integrated Audio Module)																																
S Series(SEDANS)	S60	2015	CCM(Climate control module)																																V
S Series(SEDANS)	S60	2015	AUD(AUdio Module)																																
S Series(SEDANS)	S60	2015	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S60	2015	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2015	RDAR(Remote Digital Audio Receiver)																																
S Series(SEDANS)	S60	2015	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S60	2015	PAC(Parking Assistance Camera)																																
S Series(SEDANS)	S60	2015	SODR(Side Obstacle Detection control module Right)																																
S Series(SEDANS)	S60	2015	SODL(Side Obstacle Detection control module Left)																																
S Series(SEDANS)	S60	2014	System Search																																
S Series(SEDANS)	S60	2014	ECM(Engine Control Module)																																
S Series(SEDANS)	S60	2014	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S60	2014	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S60	2014	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S60	2014	BCM(Brake Control Module)																																
S Series(SEDANS)	S60	2014	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S60	2014	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2014	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S60	2014	FSM(Forward Sensing Module)																					V											
S Series(SEDANS)	S60	2014	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S60	2014	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S60	2014	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S60	2014	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S60	2014	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S60	2014	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S60	2014	PHM(PHone Module)																															V	
S Series(SEDANS)	S60	2014	IAM(Integrated Audio Module)																																
S Series(SEDANS)	S60	2014	CCM(Climate control module)																																V
S Series(SEDANS)	S60	2014	AUD(AUdio Module)																																
S Series(SEDANS)	S60	2014	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S60	2014	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2014	RDAR(Remote Digital Audio Receiver)																																
S Series(SEDANS)	S60	2014	KVM(Keyless Vehicle Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S60	2014	PAC(Parking Assistance Camera)																																
S Series(SEDANS)	S60	2014	SODR(Side Obstacle Detection control module Right)																																
S Series(SEDANS)	S60	2014	SODL(Side Obstacle Detection control module Left)																																
S Series(SEDANS)	S60	2013	System Search																																
S Series(SEDANS)	S60	2013	ECM(Engine Control Module)																																
S Series(SEDANS)	S60	2013	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S60	2013	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S60	2013	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S60	2013	BCM(Brake Control Module)																																
S Series(SEDANS)	S60	2013	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S60	2013	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2013	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S60	2013	FSM(Forward Sensing Module)																					V											
S Series(SEDANS)	S60	2013	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S60	2013	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S60	2013	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S60	2013	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S60	2013	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S60	2013	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S60	2013	PHM(PHone Module)																															V	
S Series(SEDANS)	S60	2013	IAM(Integrated Audio Module)																																
S Series(SEDANS)	S60	2013	CCM(Climate control module)																																V
S Series(SEDANS)	S60	2013	AUD(AUdio Module)																																
S Series(SEDANS)	S60	2013	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S60	2013	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2013	RDAR(Remote Digital Audio Receiver)																																
S Series(SEDANS)	S60	2013	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S60	2013	PAC(Parking Assistance Camera)																																
S Series(SEDANS)	S60	2013	SODR(Side Obstacle Detection control module Right)																																
S Series(SEDANS)	S60	2013	SODL(Side Obstacle Detection control module Left)																																
S Series(SEDANS)	S60	2012	System Search																																
S Series(SEDANS)	S60	2012	ECM(Engine Control Module)																																
S Series(SEDANS)	S60	2012	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S60	2012	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S60	2012	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S60	2012	BCM(Brake Control Module)																																
S Series(SEDANS)	S60	2012	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S60	2012	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2012	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S60	2012	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S60	2012	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S60	2012	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S60	2012	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S60	2012	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S60	2012	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S60	2012	IAM(Integrated Audio Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S60	2012	CCM(Climate control module)																																V
S Series(SEDANS)	S60	2012	AUD(AUdio Module)																																
S Series(SEDANS)	S60	2012	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S60	2012	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2012	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S60	2011	System Search																																
S Series(SEDANS)	S60	2011	ECM(Engine Control Module)																																
S Series(SEDANS)	S60	2011	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S60	2011	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S60	2011	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S60	2011	BCM(Brake Control Module)																																
S Series(SEDANS)	S60	2011	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S60	2011	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2011	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S60	2011	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S60	2011	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S60	2011	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S60	2011	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S60	2011	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S60	2011	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S60	2011	IAM(Integrated Audio Module)																																
S Series(SEDANS)	S60	2011	CCM(Climate control module)																																V
S Series(SEDANS)	S60	2011	AUD(AUdio Module)																																
S Series(SEDANS)	S60	2011	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S60	2011	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2011	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S60	2010	System Search																																
S Series(SEDANS)	S60	2010	ECM(Engine Control Module)																																
S Series(SEDANS)	S60	2010	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S60	2010	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S60	2010	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S60	2010	BCM(Brake Control Module)																																
S Series(SEDANS)	S60	2010	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S60	2010	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2010	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S60	2010	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S60	2010	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S60	2010	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S60	2010	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S60	2010	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S60	2010	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S60	2010	IAM(Integrated Audio Module)																																
S Series(SEDANS)	S60	2010	CCM(Climate control module)																																V
S Series(SEDANS)	S60	2010	AUD(AUdio Module)																																
S Series(SEDANS)	S60	2010	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S60	2010	PSM(Power Seat Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S60	2010	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S60	2009	System Search																																
S Series(SEDANS)	S60	2009	ECM(Engine Control Module)		V	V	V	V	V	V																									
S Series(SEDANS)	S60	2009	TCM(Transmission Control Module)																																
S Series(SEDANS)	S60	2009	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S60	2009	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2009	CEM(Central Electrical Module)																																
S Series(SEDANS)	S60	2009	DIM(Driver Information Module)																																
S Series(SEDANS)	S60	2009	DDM(Driver Door Module)																																
S Series(SEDANS)	S60	2009	PDM(Passenger Door Module)																																
S Series(SEDANS)	S60	2009	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2009	CCM(Climate Control Module)																																
S Series(SEDANS)	S60	2009	SAS(Steering Wheel Angle Sensor Module)																																
S Series(SEDANS)	S60	2009	UEM(Up Electrical Module)																																
S Series(SEDANS)	S60	2009	REM(Rear Electrical Module)																																
S Series(SEDANS)	S60	2009	AUM(Audio Module)																																
S Series(SEDANS)	S60	2008	System Search																																
S Series(SEDANS)	S60	2008	ECM(Engine Control Module)		V	V	V	V	V	V																									
S Series(SEDANS)	S60	2008	TCM(Transmission Control Module)																																
S Series(SEDANS)	S60	2008	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S60	2008	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2008	CEM(Central Electrical Module)																																
S Series(SEDANS)	S60	2008	DIM(Driver Information Module)																																
S Series(SEDANS)	S60	2008	DDM(Driver Door Module)																																
S Series(SEDANS)	S60	2008	PDM(Passenger Door Module)																																
S Series(SEDANS)	S60	2008	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2008	CCM(Climate Control Module)																																
S Series(SEDANS)	S60	2008	SAS(Steering Wheel Angle Sensor Module)																																
S Series(SEDANS)	S60	2008	UEM(Up Electrical Module)																																
S Series(SEDANS)	S60	2008	REM(Rear Electrical Module)																																
S Series(SEDANS)	S60	2008	AUM(Audio Module)																																
S Series(SEDANS)	S60	2007	System Search																																
S Series(SEDANS)	S60	2007	ECM(Engine Control Module)		V	V	V	V	V	V																									
S Series(SEDANS)	S60	2007	TCM(Transmission Control Module)																																
S Series(SEDANS)	S60	2007	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S60	2007	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2007	CEM(Central Electrical Module)																																
S Series(SEDANS)	S60	2007	DIM(Driver Information Module)																																
S Series(SEDANS)	S60	2007	DDM(Driver Door Module)																																
S Series(SEDANS)	S60	2007	PDM(Passenger Door Module)																																
S Series(SEDANS)	S60	2007	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2007	CCM(Climate Control Module)																																
S Series(SEDANS)	S60	2007	SAS(Steering Wheel Angle Sensor Module)																																
S Series(SEDANS)	S60	2007	UEM(Up Electrical Module)																																
S Series(SEDANS)	S60	2007	REM(Rear Electrical Module)																																
S Series(SEDANS)	S60	2007	AUM(Audio Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S60	2006	System Search																																
S Series(SEDANS)	S60	2006	ECM(Engine Control Module)																																
S Series(SEDANS)	S60	2006	TCM(Transmission Control Module)																																
S Series(SEDANS)	S60	2006	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S60	2006	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2006	CEM(Central Electrical Module)																																
S Series(SEDANS)	S60	2006	DIM(Driver Information Module)																																
S Series(SEDANS)	S60	2006	DDM(Driver Door Module)																																
S Series(SEDANS)	S60	2006	PDM(Passenger Door Module)																																
S Series(SEDANS)	S60	2006	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2006	CCM(Climate Control Module)																																
S Series(SEDANS)	S60	2006	SAS(Steering Wheel Angle Sensor Module)																																
S Series(SEDANS)	S60	2006	UEM(Up Electrical Module)																																
S Series(SEDANS)	S60	2006	REM(Rear Electrical Module)																																
S Series(SEDANS)	S60	2006	AUM(Audio Module)																																
S Series(SEDANS)	S60	2005	System Search																																
S Series(SEDANS)	S60	2005	ECM(Engine Control Module)																																
S Series(SEDANS)	S60	2005	TCM(Transmission Control Module)																																
S Series(SEDANS)	S60	2005	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S60	2005	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2005	CEM(Central Electrical Module)																																
S Series(SEDANS)	S60	2005	DIM(Driver Information Module)																																
S Series(SEDANS)	S60	2005	DDM(Driver Door Module)																																
S Series(SEDANS)	S60	2005	PDM(Passenger Door Module)																																
S Series(SEDANS)	S60	2005	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2005	CCM(Climate Control Module)																																
S Series(SEDANS)	S60	2005	SAS(Steering Wheel Angle Sensor Module)																																
S Series(SEDANS)	S60	2005	UEM(Up Electrical Module)																																
S Series(SEDANS)	S60	2005	REM(Rear Electrical Module)																																
S Series(SEDANS)	S60	2005	AUM(Audio Module)																																
S Series(SEDANS)	S60	2004	System Search																																
S Series(SEDANS)	S60	2004	ECM(Engine Control Module)																																
S Series(SEDANS)	S60	2004	TCM(Transmission Control Module)																																
S Series(SEDANS)	S60	2004	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S60	2004	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2004	CEM(Central Electrical Module)																																
S Series(SEDANS)	S60	2004	DIM(Driver Information Module)																																
S Series(SEDANS)	S60	2004	DDM(Driver Door Module)																																
S Series(SEDANS)	S60	2004	PDM(Passenger Door Module)																																
S Series(SEDANS)	S60	2004	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2004	CCM(Climate Control Module)																																
S Series(SEDANS)	S60	2004	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S60	2004	UEM(Up Electrical Module)																																
S Series(SEDANS)	S60	2004	REM(Rear Electrical Module)																																
S Series(SEDANS)	S60	2004	AUM(Audio Module)																																
S Series(SEDANS)	S60	2003	System Search																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S60	2003	ECM(Engine Control Module)																																
S Series(SEDANS)	S60	2003	TCM(Transmission Control Module)																																
S Series(SEDANS)	S60	2003	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S60	2003	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2003	CEM(Central Electrical Module)																																
S Series(SEDANS)	S60	2003	DIM(Driver Information Module)																																
S Series(SEDANS)	S60	2003	DDM(Driver Door Module)																																
S Series(SEDANS)	S60	2003	PDM(Passenger Door Module)																																
S Series(SEDANS)	S60	2003	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2003	CCM(Climate Control Module)																																
S Series(SEDANS)	S60	2003	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S60	2003	UEM(Up Electrical Module)																																
S Series(SEDANS)	S60	2003	REM(Rear Electrical Module)																																
S Series(SEDANS)	S60	2003	AUM(Audio Module)																																
S Series(SEDANS)	S60	2002	System Search																																
S Series(SEDANS)	S60	2002	ECM(Engine Control Module)																																
S Series(SEDANS)	S60	2002	TCM(Transmission Control Module)																																
S Series(SEDANS)	S60	2002	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S60	2002	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2002	CEM(Central Electrical Module)																																
S Series(SEDANS)	S60	2002	DIM(Driver Information Module)																																
S Series(SEDANS)	S60	2002	DDM(Driver Door Module)																																
S Series(SEDANS)	S60	2002	PDM(Passenger Door Module)																																
S Series(SEDANS)	S60	2002	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2002	CCM(Climate Control Module)																																
S Series(SEDANS)	S60	2002	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S60	2002	UEM(Up Electrical Module)																																
S Series(SEDANS)	S60	2002	REM(Rear Electrical Module)																																
S Series(SEDANS)	S60	2002	AUM(Audio Module)																																
S Series(SEDANS)	S60	2001	System Search																																
S Series(SEDANS)	S60	2001	ECM(Engine Control Module)																																
S Series(SEDANS)	S60	2001	TCM(Transmission Control Module)																																
S Series(SEDANS)	S60	2001	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S60	2001	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S60	2001	CEM(Central Electrical Module)																																
S Series(SEDANS)	S60	2001	DIM(Driver Information Module)																																
S Series(SEDANS)	S60	2001	DDM(Driver Door Module)																																
S Series(SEDANS)	S60	2001	PDM(Passenger Door Module)																																
S Series(SEDANS)	S60	2001	PSM(Power Seat Module)																																
S Series(SEDANS)	S60	2001	CCM(Climate Control Module)																																
S Series(SEDANS)	S60	2001	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S60	2001	UEM(Up Electrical Module)																																
S Series(SEDANS)	S60	2001	REM(Rear Electrical Module)																																
S Series(SEDANS)	S60	2001	AUM(Audio Module)																																
S Series(SEDANS)	S70	2000	System Search																																
S Series(SEDANS)	S70	2000	ECM(Engine Control Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S70	2000	TCM(Transmission Control Module)																																
S Series(SEDANS)	S70	2000	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S70	1999	System Search																																
S Series(SEDANS)	S70	1999	ECM(Engine Control Module)																																
S Series(SEDANS)	S70	1999	TCM(Transmission Control Module)																																
S Series(SEDANS)	S70	1999	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S80	2014	System Search																																
S Series(SEDANS)	S80	2014	ECM(Engine Control Module)																																
S Series(SEDANS)	S80	2014	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S80	2014	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S80	2014	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S80	2014	BCM(Brake Control Module)																																
S Series(SEDANS)	S80	2014	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S80	2014	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2014	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S80	2014	FSM(Forward Sensing Module)																					V											
S Series(SEDANS)	S80	2014	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S80	2014	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S80	2014	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S80	2014	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S80	2014	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S80	2014	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S80	2014	CCM(Climate control module)																																
S Series(SEDANS)	S80	2014	AUD(AUdio Module)																																
S Series(SEDANS)	S80	2014	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S80	2014	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2014	DEM(Differential Electronic Module)																																
S Series(SEDANS)	S80	2014	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S80	2014	POT(Power operated tailgate module)																																
S Series(SEDANS)	S80	2014	SODR(Side Obstacle Detection control module Right)																																
S Series(SEDANS)	S80	2014	SODL(Side Obstacle Detection control module Left)																																
S Series(SEDANS)	S80	2014	RDAR(Remote Digital Audio Receiver)																																
S Series(SEDANS)	S80	2014	HCM(Headlamp control module)																																
S Series(SEDANS)	S80	2014	BPM(Bluetooth phone module)																																
S Series(SEDANS)	S80	2013	System Search																																
S Series(SEDANS)	S80	2013	ECM(Engine Control Module)																																
S Series(SEDANS)	S80	2013	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S80	2013	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S80	2013	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S80	2013	BCM(Brake Control Module)																																
S Series(SEDANS)	S80	2013	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S80	2013	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2013	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S80	2013	FSM(Forward Sensing Module)																					V											
S Series(SEDANS)	S80	2013	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S80	2013	DIM(Driver Information Module)																						V	V	V	V	V						

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S80	2013	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S80	2013	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S80	2013	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S80	2013	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S80	2013	CCM(Climate control module)																																
S Series(SEDANS)	S80	2013	AUD(AUdio Module)																																
S Series(SEDANS)	S80	2013	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S80	2013	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2013	DEM(Differential Electronic Module)																																
S Series(SEDANS)	S80	2013	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S80	2013	POT(Power operated tailgate module)																																
S Series(SEDANS)	S80	2013	SODR(Side Obstacle Detection control module Right)																																
S Series(SEDANS)	S80	2013	SODL(Side Obstacle Detection control module Left)																																
S Series(SEDANS)	S80	2013	RDAR(Remote Digital Audio Receiver)																																
S Series(SEDANS)	S80	2013	HCM(Headlamp control module)																																
S Series(SEDANS)	S80	2013	BPM(Bluetooth phone module)																																
S Series(SEDANS)	S80	2012	System Search																																
S Series(SEDANS)	S80	2012	ECM(Engine Control Module)																																
S Series(SEDANS)	S80	2012	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S80	2012	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S80	2012	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S80	2012	BCM(Brake Control Module)																																
S Series(SEDANS)	S80	2012	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S80	2012	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2012	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S80	2012	FSM(Forward Sensing Module)																					V											
S Series(SEDANS)	S80	2012	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S80	2012	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S80	2012	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S80	2012	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S80	2012	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S80	2012	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S80	2012	CCM(Climate control module)																																
S Series(SEDANS)	S80	2012	AUD(AUdio Module)																																
S Series(SEDANS)	S80	2012	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S80	2012	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2012	DEM(Differential Electronic Module)																																
S Series(SEDANS)	S80	2012	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S80	2012	POT(Power operated tailgate module)																																
S Series(SEDANS)	S80	2012	SODR(Side Obstacle Detection control module Right)																																
S Series(SEDANS)	S80	2012	SODL(Side Obstacle Detection control module Left)																																
S Series(SEDANS)	S80	2012	RDAR(Remote Digital Audio Receiver)																																
S Series(SEDANS)	S80	2012	HCM(Headlamp control module)																																
S Series(SEDANS)	S80	2012	BPM(Bluetooth phone module)																																
S Series(SEDANS)	S80	2011	System Search																																
S Series(SEDANS)	S80	2011	ECM(Engine Control Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S80	2011	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S80	2011	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S80	2011	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S80	2011	BCM(Brake Control Module)																																
S Series(SEDANS)	S80	2011	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S80	2011	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2011	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S80	2011	FSM(Forward Sensing Module)																					V											
S Series(SEDANS)	S80	2011	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S80	2011	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S80	2011	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S80	2011	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S80	2011	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S80	2011	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S80	2011	CCM(Climate control module)																																
S Series(SEDANS)	S80	2011	AUD(AUdio Module)																																
S Series(SEDANS)	S80	2011	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S80	2011	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2011	DEM(Differential Electronic Module)																																
S Series(SEDANS)	S80	2011	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S80	2011	POT(Power operated tailgate module)																																
S Series(SEDANS)	S80	2011	SODR(Side Obstacle Detection control module Right)																																
S Series(SEDANS)	S80	2011	SODL(Side Obstacle Detection control module Left)																																
S Series(SEDANS)	S80	2011	RDAR(Remote Digital Audio Receiver)																																
S Series(SEDANS)	S80	2011	HCM(Headlamp control module)																																
S Series(SEDANS)	S80	2011	BPM(Bluetooth phone module)																																
S Series(SEDANS)	S80	2010	System Search																																
S Series(SEDANS)	S80	2010	ECM(Engine Control Module)		V	V	V	V	V	V																									
S Series(SEDANS)	S80	2010	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S80	2010	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S80	2010	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S80	2010	BCM(Brake Control Module)																																
S Series(SEDANS)	S80	2010	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S80	2010	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2010	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S80	2010	FSM(Forward Sensing Module)																					V											
S Series(SEDANS)	S80	2010	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S80	2010	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S80	2010	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S80	2010	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S80	2010	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S80	2010	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S80	2010	CCM(Climate control module)																																
S Series(SEDANS)	S80	2010	AUD(AUdio Module)																																
S Series(SEDANS)	S80	2010	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S80	2010	PSM(Power Seat Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S80	2010	DEM(Differential Electronic Module)																																
S Series(SEDANS)	S80	2010	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S80	2010	POT(Power operated tailgate module)																																
S Series(SEDANS)	S80	2010	SODR(Side Obstacle Detection control module Right)																																
S Series(SEDANS)	S80	2010	SODL(Side Obstacle Detection control module Left)																																
S Series(SEDANS)	S80	2010	RDAR(Remote Digital Audio Receiver)																																
S Series(SEDANS)	S80	2010	HCM(Headlamp control module)																																
S Series(SEDANS)	S80	2010	BPM(Bluetooth phone module)																																
S Series(SEDANS)	S80	2009	System Search																																
S Series(SEDANS)	S80	2009	ECM(Engine Control Module)		V	V	V	V	V	V																									
S Series(SEDANS)	S80	2009	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S80	2009	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S80	2009	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S80	2009	BCM(Brake Control Module)																																
S Series(SEDANS)	S80	2009	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S80	2009	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2009	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S80	2009	FSM(Forward Sensing Module)																					V											
S Series(SEDANS)	S80	2009	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S80	2009	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S80	2009	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S80	2009	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S80	2009	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S80	2009	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S80	2009	CCM(Climate control module)																																
S Series(SEDANS)	S80	2009	AUD(AUdio Module)																																
S Series(SEDANS)	S80	2009	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S80	2009	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2009	DEM(Differential Electronic Module)																																
S Series(SEDANS)	S80	2009	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S80	2009	POT(Power operated tailgate module)																																
S Series(SEDANS)	S80	2009	SODR(Side Obstacle Detection control module Right)																																
S Series(SEDANS)	S80	2009	SODL(Side Obstacle Detection control module Left)																																
S Series(SEDANS)	S80	2009	RDAR(Remote Digital Audio Receiver)																																
S Series(SEDANS)	S80	2009	HCM(Headlamp control module)																																
S Series(SEDANS)	S80	2009	BPM(Bluetooth phone module)																																
S Series(SEDANS)	S80	2008	System Search																																
S Series(SEDANS)	S80	2008	ECM(Engine Control Module)		V	V	V	V	V	V																									
S Series(SEDANS)	S80	2008	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S80	2008	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S80	2008	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S80	2008	BCM(Brake Control Module)																																
S Series(SEDANS)	S80	2008	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S80	2008	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2008	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S80	2008	FSM(Forward Sensing Module)																					V											

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S80	2008	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S80	2008	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S80	2008	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S80	2008	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S80	2008	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S80	2008	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S80	2008	CCM(Climate control module)																																
S Series(SEDANS)	S80	2008	AUD(AUdio Module)																																
S Series(SEDANS)	S80	2008	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S80	2008	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2008	DEM(Differential Electronic Module)																																
S Series(SEDANS)	S80	2008	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S80	2008	POT(Power operated tailgate module)																																
S Series(SEDANS)	S80	2008	SODR(Side Obstacle Detection control module Right)																																
S Series(SEDANS)	S80	2008	SODL(Side Obstacle Detection control module Left)																																
S Series(SEDANS)	S80	2008	RDAR(Remote Digital Audio Receiver)																																
S Series(SEDANS)	S80	2008	HCM(Headlamp control module)																																
S Series(SEDANS)	S80	2008	BPM(Bluetooth phone module)																																
S Series(SEDANS)	S80	2007	System Search																																
S Series(SEDANS)	S80	2007	ECM(Engine Control Module)		V	V	V	V	V	V																									
S Series(SEDANS)	S80	2007	TCM(Transmission Control Module)	TF-80SC																															
S Series(SEDANS)	S80	2007	TCM(Transmission Control Module)	TG-81SC																															
S Series(SEDANS)	S80	2007	SAS(Steering Angle Sensor module)																																
S Series(SEDANS)	S80	2007	BCM(Brake Control Module)																																
S Series(SEDANS)	S80	2007	PBM(Park Brake Module)																				V												
S Series(SEDANS)	S80	2007	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2007	PSCM(Power Steering Control Module)																																
S Series(SEDANS)	S80	2007	FSM(Forward Sensing Module)																					V											
S Series(SEDANS)	S80	2007	CVM(Closing Velocity Module)																																
S Series(SEDANS)	S80	2007	DIM(Driver Information Module)																						V	V	V	V	V						
S Series(SEDANS)	S80	2007	PAM(Parking Assistance Module)																											V					
S Series(SEDANS)	S80	2007	CEM(Central Electrical Module)																												V				
S Series(SEDANS)	S80	2007	ICM(Infotainment Control Module)																																
S Series(SEDANS)	S80	2007	PDM(Passenger door module)																													V	V		
S Series(SEDANS)	S80	2007	CCM(Climate control module)																																
S Series(SEDANS)	S80	2007	AUD(AUdio Module)																																
S Series(SEDANS)	S80	2007	DDM(Driver Door Module)																													V	V		
S Series(SEDANS)	S80	2007	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2007	DEM(Differential Electronic Module)																																
S Series(SEDANS)	S80	2007	KVM(Keyless Vehicle Module)																																
S Series(SEDANS)	S80	2007	POT(Power operated tailgate module)																																
S Series(SEDANS)	S80	2007	SODR(Side Obstacle Detection control module Right)																																
S Series(SEDANS)	S80	2007	SODL(Side Obstacle Detection control module Left)																																
S Series(SEDANS)	S80	2007	RDAR(Remote Digital Audio Receiver)																																
S Series(SEDANS)	S80	2007	HCM(Headlamp control module)																																
S Series(SEDANS)	S80	2007	BPM(Bluetooth phone module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S80	2006	System Search																																
S Series(SEDANS)	S80	2006	ECM(Engine Control Module)																																
S Series(SEDANS)	S80	2006	TCM(Transmission Control Module)																																
S Series(SEDANS)	S80	2006	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S80	2006	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2006	CEM(Central Electrical Module)																																
S Series(SEDANS)	S80	2006	DIM(Driver Information Module)																																
S Series(SEDANS)	S80	2006	DDM(Driver Door Module)																																
S Series(SEDANS)	S80	2006	PDM(Passenger Door Module)																																
S Series(SEDANS)	S80	2006	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2006	CCM(Climate Control Module)																																
S Series(SEDANS)	S80	2006	SAS(Steering Wheel Angle Sensor Module)																																
S Series(SEDANS)	S80	2006	UEM(Up Electrical Module)																																
S Series(SEDANS)	S80	2006	REM(Rear Electrical Module)																																
S Series(SEDANS)	S80	2006	AUM(Audio Module)																																
S Series(SEDANS)	S80	2005	System Search																																
S Series(SEDANS)	S80	2005	ECM(Engine Control Module)																																
S Series(SEDANS)	S80	2005	TCM(Transmission Control Module)																																
S Series(SEDANS)	S80	2005	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S80	2005	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2005	CEM(Central Electrical Module)																																
S Series(SEDANS)	S80	2005	DIM(Driver Information Module)																																
S Series(SEDANS)	S80	2005	DDM(Driver Door Module)																																
S Series(SEDANS)	S80	2005	PDM(Passenger Door Module)																																
S Series(SEDANS)	S80	2005	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2005	CCM(Climate Control Module)																																
S Series(SEDANS)	S80	2005	SAS(Steering Wheel Angle Sensor Module)																																
S Series(SEDANS)	S80	2005	UEM(Up Electrical Module)																																
S Series(SEDANS)	S80	2005	REM(Rear Electrical Module)																																
S Series(SEDANS)	S80	2005	AUM(Audio Module)																																
S Series(SEDANS)	S80	2004	System Search																																
S Series(SEDANS)	S80	2004	ECM(Engine Control Module)																																
S Series(SEDANS)	S80	2004	TCM(Transmission Control Module)																																
S Series(SEDANS)	S80	2004	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S80	2004	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2004	CEM(Central Electrical Module)																																
S Series(SEDANS)	S80	2004	DIM(Driver Information Module)																																
S Series(SEDANS)	S80	2004	DDM(Driver Door Module)																																
S Series(SEDANS)	S80	2004	PDM(Passenger Door Module)																																
S Series(SEDANS)	S80	2004	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2004	CCM(Climate Control Module)																																
S Series(SEDANS)	S80	2004	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S80	2004	UEM(Up Electrical Module)																																
S Series(SEDANS)	S80	2004	REM(Rear Electrical Module)																																
S Series(SEDANS)	S80	2004	AUM(Audio Module)																																
S Series(SEDANS)	S80	2003	System Search																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S80	2003	ECM(Engine Control Module)																																
S Series(SEDANS)	S80	2003	TCM(Transmission Control Module)																																
S Series(SEDANS)	S80	2003	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S80	2003	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2003	CEM(Central Electrical Module)																																
S Series(SEDANS)	S80	2003	DIM(Driver Information Module)																																
S Series(SEDANS)	S80	2003	DDM(Driver Door Module)																																
S Series(SEDANS)	S80	2003	PDM(Passenger Door Module)																																
S Series(SEDANS)	S80	2003	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2003	CCM(Climate Control Module)																																
S Series(SEDANS)	S80	2003	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S80	2003	UEM(Up Electrical Module)																																
S Series(SEDANS)	S80	2003	REM(Rear Electrical Module)																																
S Series(SEDANS)	S80	2003	AUM(Audio Module)																																
S Series(SEDANS)	S80	2002	System Search																																
S Series(SEDANS)	S80	2002	ECM(Engine Control Module)																																
S Series(SEDANS)	S80	2002	TCM(Transmission Control Module)																																
S Series(SEDANS)	S80	2002	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S80	2002	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2002	CEM(Central Electrical Module)																																
S Series(SEDANS)	S80	2002	DIM(Driver Information Module)																																
S Series(SEDANS)	S80	2002	DDM(Driver Door Module)																																
S Series(SEDANS)	S80	2002	PDM(Passenger Door Module)																																
S Series(SEDANS)	S80	2002	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2002	CCM(Climate Control Module)																																
S Series(SEDANS)	S80	2002	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S80	2002	UEM(Up Electrical Module)																																
S Series(SEDANS)	S80	2002	REM(Rear Electrical Module)																																
S Series(SEDANS)	S80	2002	AUM(Audio Module)																																
S Series(SEDANS)	S80	2001	System Search																																
S Series(SEDANS)	S80	2001	ECM(Engine Control Module)																																
S Series(SEDANS)	S80	2001	TCM(Transmission Control Module)																																
S Series(SEDANS)	S80	2001	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S80	2001	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2001	CEM(Central Electrical Module)																																
S Series(SEDANS)	S80	2001	DIM(Driver Information Module)																																
S Series(SEDANS)	S80	2001	DDM(Driver Door Module)																																
S Series(SEDANS)	S80	2001	PDM(Passenger Door Module)																																
S Series(SEDANS)	S80	2001	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2001	CCM(Climate Control Module)																																
S Series(SEDANS)	S80	2001	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S80	2001	UEM(Up Electrical Module)																																
S Series(SEDANS)	S80	2001	REM(Rear Electrical Module)																																
S Series(SEDANS)	S80	2001	AUM(Audio Module)																																
S Series(SEDANS)	S80	2000	System Search																																
S Series(SEDANS)	S80	2000	ECM(Engine Control Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
S Series(SEDANS)	S80	2000	TCM(Transmission Control Module)																																
S Series(SEDANS)	S80	2000	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S80	2000	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	2000	CEM(Central Electrical Module)																																
S Series(SEDANS)	S80	2000	DIM(Driver Information Module)																																
S Series(SEDANS)	S80	2000	DDM(Driver Door Module)																																
S Series(SEDANS)	S80	2000	PDM(Passenger Door Module)																																
S Series(SEDANS)	S80	2000	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	2000	CCM(Climate Control Module)																																
S Series(SEDANS)	S80	2000	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S80	2000	UEM(Up Electrical Module)																																
S Series(SEDANS)	S80	2000	REM(Rear Electrical Module)																																
S Series(SEDANS)	S80	2000	AUM(Audio Module)																																
S Series(SEDANS)	S80	1999	System Search																																
S Series(SEDANS)	S80	1999	ECM(Engine Control Module)																																
S Series(SEDANS)	S80	1999	TCM(Transmission Control Module)																																
S Series(SEDANS)	S80	1999	ABS(Anti-Lock Brake System)																																
S Series(SEDANS)	S80	1999	SRS(Supplemental Restraint System)																																
S Series(SEDANS)	S80	1999	CEM(Central Electrical Module)																																
S Series(SEDANS)	S80	1999	DIM(Driver Information Module)																																
S Series(SEDANS)	S80	1999	DDM(Driver Door Module)																																
S Series(SEDANS)	S80	1999	PDM(Passenger Door Module)																																
S Series(SEDANS)	S80	1999	PSM(Power Seat Module)																																
S Series(SEDANS)	S80	1999	CCM(Climate Control Module)																																
S Series(SEDANS)	S80	1999	SWM(Steering Wheel Module)																																
S Series(SEDANS)	S80	1999	UEM(Up Electrical Module)																																
S Series(SEDANS)	S80	1999	REM(Rear Electrical Module)																																
S Series(SEDANS)	S80	1999	AUM(Audio Module)																																
V Series(WAGONS)	Maintenance	BCM(Brake control module) Service function																																	
V Series(WAGONS)	Maintenance	PBM(Parking brake module) Service function																																	
V Series(WAGONS)	Maintenance	Service Reminder Reset																																	
V Series(WAGONS)	Maintenance	Technical Information																																	
V Series(WAGONS)	V40	2014	System Search																																
V Series(WAGONS)	V40	2014	ECM(Engine Control Module)																																
V Series(WAGONS)	V40	2014	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V40	2014	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V40	2014	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V40	2014	BCM(Brake Control Module)																																
V Series(WAGONS)	V40	2014	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V40	2014	PSCM(Power Steering Control Module)																																
V Series(WAGONS)	V40	2014	CVM(Closing Velocity Module)																																
V Series(WAGONS)	V40	2014	DIM(Driver Information Module)																					V	V	V	V	V							
V Series(WAGONS)	V40	2014	FSM(Forward Sensing Module)																				V												
V Series(WAGONS)	V40	2014	PAM(Parking Assistance Module)																																
V Series(WAGONS)	V40	2014	CEM(Central Electrical Module)								V																				V				
V Series(WAGONS)	V40	2014	ICM(Infotainment Control Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
V Series(WAGONS)	V40	2014	PDM(Passenger door module)																													V	V		
V Series(WAGONS)	V40	2014	IAM(Integrated Audio Module)																																
V Series(WAGONS)	V40	2014	CCM(Climate control module)																																V
V Series(WAGONS)	V40	2014	AUD(AUdio Module)																																
V Series(WAGONS)	V40	2014	DDM(Driver Door Module)																													V	V		
V Series(WAGONS)	V40	2014	PPM(Pedestrian Protection Module)																																
V Series(WAGONS)	V40	2014	SODR(Side Obstacle Detection control module Right)																																
V Series(WAGONS)	V40	2014	SODL(Side Obstacle Detection control module Left)																																
V Series(WAGONS)	V40	2013	System Search																																
V Series(WAGONS)	V40	2013	ECM(Engine Control Module)																																
V Series(WAGONS)	V40	2013	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V40	2013	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V40	2013	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V40	2013	BCM(Brake Control Module)																																
V Series(WAGONS)	V40	2013	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V40	2013	PSCM(Power Steering Control Module)																																
V Series(WAGONS)	V40	2013	CVM(Closing Velocity Module)																																
V Series(WAGONS)	V40	2013	DIM(Driver Information Module)																						V	V	V	V	V						
V Series(WAGONS)	V40	2013	PAM(Parking Assistance Module)																																
V Series(WAGONS)	V40	2013	FSM(Forward Sensing Module)																					V											
V Series(WAGONS)	V40	2013	CEM(Central Electrical Module)								V																				V				
V Series(WAGONS)	V40	2013	ICM(Infotainment Control Module)																																
V Series(WAGONS)	V40	2013	PDM(Passenger door module)																													V	V		
V Series(WAGONS)	V40	2013	IAM(Integrated Audio Module)																																
V Series(WAGONS)	V40	2013	CCM(Climate control module)																																V
V Series(WAGONS)	V40	2013	AUD(AUdio Module)																																
V Series(WAGONS)	V40	2013	DDM(Driver Door Module)																													V	V		
V Series(WAGONS)	V40	2013	PPM(Pedestrian Protection Module)																																
V Series(WAGONS)	V40	2013	SODR(Side Obstacle Detection control module Right)																																
V Series(WAGONS)	V40	2013	SODL(Side Obstacle Detection control module Left)																																
V Series(WAGONS)	V40	2012	System Search																																
V Series(WAGONS)	V40	2012	ECM(Engine Control Module)																																
V Series(WAGONS)	V40	2012	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V40	2012	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V40	2012	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V40	2012	BCM(Brake Control Module)																																
V Series(WAGONS)	V40	2012	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V40	2012	PSCM(Power Steering Control Module)																																
V Series(WAGONS)	V40	2012	CVM(Closing Velocity Module)																																
V Series(WAGONS)	V40	2012	DIM(Driver Information Module)																						V	V	V	V	V						
V Series(WAGONS)	V40	2012	PAM(Parking Assistance Module)																																
V Series(WAGONS)	V40	2012	FSM(Forward Sensing Module)																					V											
V Series(WAGONS)	V40	2012	CEM(Central Electrical Module)								V																				V				
V Series(WAGONS)	V40	2012	ICM(Infotainment Control Module)																																
V Series(WAGONS)	V40	2012	PDM(Passenger door module)																													V	V		
V Series(WAGONS)	V40	2012	IAM(Integrated Audio Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
V Series(WAGONS)	V40	2012	CCM(Climate control module)																																V
V Series(WAGONS)	V40	2012	AUD(AUdio Module)																																
V Series(WAGONS)	V40	2012	DDM(Driver Door Module)																												V	V			
V Series(WAGONS)	V40	2012	PPM(Pedestrian Protection Module)																																
V Series(WAGONS)	V40	2012	SODR(Side Obstacle Detection control module Right)																																
V Series(WAGONS)	V40	2012	SODL(Side Obstacle Detection control module Left)																																
V Series(WAGONS)	V50	2012	System Search																																
V Series(WAGONS)	V50	2012	ECM(Engine Control Module)																																
V Series(WAGONS)	V50	2012	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V50	2012	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V50	2012	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V50	2012	BCM(Brake Control Module)																																
V Series(WAGONS)	V50	2012	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V50	2012	DIM(Driver Information Module)																																
V Series(WAGONS)	V50	2012	PDM(Passenger door module)																																
V Series(WAGONS)	V50	2012	CCM(Climate control module)																																
V Series(WAGONS)	V50	2012	DDM(Driver Door Module)																																
V Series(WAGONS)	V50	2012	EPS(Electrical power steering module)																																
V Series(WAGONS)	V50	2012	HCM(Headlamp control module)																																
V Series(WAGONS)	V50	2011	System Search																																
V Series(WAGONS)	V50	2011	ECM(Engine Control Module)																																
V Series(WAGONS)	V50	2011	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V50	2011	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V50	2011	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V50	2011	BCM(Brake Control Module)																																
V Series(WAGONS)	V50	2011	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V50	2011	DIM(Driver Information Module)																																
V Series(WAGONS)	V50	2011	PDM(Passenger door module)																																
V Series(WAGONS)	V50	2011	CCM(Climate control module)																																
V Series(WAGONS)	V50	2011	DDM(Driver Door Module)																																
V Series(WAGONS)	V50	2011	EPS(Electrical power steering module)																																
V Series(WAGONS)	V50	2011	HCM(Headlamp control module)																																
V Series(WAGONS)	V50	2010	System Search																																
V Series(WAGONS)	V50	2010	ECM(Engine Control Module)																																
V Series(WAGONS)	V50	2010	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V50	2010	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V50	2010	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V50	2010	BCM(Brake Control Module)																																
V Series(WAGONS)	V50	2010	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V50	2010	DIM(Driver Information Module)																																
V Series(WAGONS)	V50	2010	PDM(Passenger door module)																																
V Series(WAGONS)	V50	2010	CCM(Climate control module)																																
V Series(WAGONS)	V50	2010	DDM(Driver Door Module)																																
V Series(WAGONS)	V50	2010	EPS(Electrical power steering module)																																
V Series(WAGONS)	V50	2010	HCM(Headlamp control module)																																
V Series(WAGONS)	V50	2010	ABS(Anti-Lock Brake System)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
V Series(WAGONS)	V50	2010	CEM(Central Electrical Module)																																
V Series(WAGONS)	V50	2010	PSM(Power Seat Module)																																
V Series(WAGONS)	V50	2010	SWM(Steering Wheel Module)																																
V Series(WAGONS)	V50	2009	System Search																																
V Series(WAGONS)	V50	2009	ECM(Engine Control Module)																																
V Series(WAGONS)	V50	2009	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V50	2009	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V50	2009	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V50	2009	BCM(Brake Control Module)																																
V Series(WAGONS)	V50	2009	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V50	2009	DIM(Driver Information Module)																																
V Series(WAGONS)	V50	2009	PDM(Passenger door module)																																
V Series(WAGONS)	V50	2009	CCM(Climate control module)																																
V Series(WAGONS)	V50	2009	DDM(Driver Door Module)																																
V Series(WAGONS)	V50	2009	EPS(Electrical power steering module)																																
V Series(WAGONS)	V50	2009	HCM(Headlamp control module)																																
V Series(WAGONS)	V50	2009	ABS(Anti-Lock Brake System)																																
V Series(WAGONS)	V50	2009	CEM(Central Electrical Module)																																
V Series(WAGONS)	V50	2009	PSM(Power Seat Module)																																
V Series(WAGONS)	V50	2009	SWM(Steering Wheel Module)																																
V Series(WAGONS)	V50	2008	System Search																																
V Series(WAGONS)	V50	2008	ECM(Engine Control Module)		V	V	V	V	V	V																									
V Series(WAGONS)	V50	2008	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V50	2008	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V50	2008	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V50	2008	BCM(Brake Control Module)																																
V Series(WAGONS)	V50	2008	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V50	2008	DIM(Driver Information Module)																																
V Series(WAGONS)	V50	2008	PDM(Passenger door module)																																
V Series(WAGONS)	V50	2008	CCM(Climate control module)																																
V Series(WAGONS)	V50	2008	DDM(Driver Door Module)																																
V Series(WAGONS)	V50	2008	EPS(Electrical power steering module)																																
V Series(WAGONS)	V50	2008	HCM(Headlamp control module)																																
V Series(WAGONS)	V50	2008	ABS(Anti-Lock Brake System)																																
V Series(WAGONS)	V50	2008	CEM(Central Electrical Module)																																
V Series(WAGONS)	V50	2008	PSM(Power Seat Module)																																
V Series(WAGONS)	V50	2008	SWM(Steering Wheel Module)																																
V Series(WAGONS)	V50	2007	System Search																																
V Series(WAGONS)	V50	2007	ECM(Engine Control Module)		V	V	V	V	V	V																									
V Series(WAGONS)	V50	2007	TCM(Transmission Control Module)																																
V Series(WAGONS)	V50	2007	ABS(Anti-Lock Brake System)																																
V Series(WAGONS)	V50	2007	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V50	2007	CEM(Central Electrical Module)																																
V Series(WAGONS)	V50	2007	DIM(Driver Information Module)																																
V Series(WAGONS)	V50	2007	DDM(Driver Door Module)																																
V Series(WAGONS)	V50	2007	PDM(Passenger Door Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
V Series(WAGONS)	V50	2007	PSM(Power Seat Module)																																
V Series(WAGONS)	V50	2007	CCM(Climate Control Module)																																
V Series(WAGONS)	V50	2007	SWM(Steering Wheel Module)																																
V Series(WAGONS)	V50	2006	System Search																																
V Series(WAGONS)	V50	2006	ECM(Engine Control Module)																																
V Series(WAGONS)	V50	2006	TCM(Transmission Control Module)																																
V Series(WAGONS)	V50	2006	ABS(Anti-Lock Brake System)																																
V Series(WAGONS)	V50	2006	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V50	2006	CEM(Central Electrical Module)																																
V Series(WAGONS)	V50	2006	DIM(Driver Information Module)																																
V Series(WAGONS)	V50	2006	DDM(Driver Door Module)																																
V Series(WAGONS)	V50	2006	PDM(Passenger Door Module)																																
V Series(WAGONS)	V50	2006	PSM(Power Seat Module)																																
V Series(WAGONS)	V50	2006	CCM(Climate Control Module)																																
V Series(WAGONS)	V50	2006	SWM(Steering Wheel Module)																																
V Series(WAGONS)	V50	2005	System Search																																
V Series(WAGONS)	V50	2005	ECM(Engine Control Module)																																
V Series(WAGONS)	V50	2005	TCM(Transmission Control Module)																																
V Series(WAGONS)	V50	2005	ABS(Anti-Lock Brake System)																																
V Series(WAGONS)	V50	2005	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V50	2005	CEM(Central Electrical Module)																																
V Series(WAGONS)	V50	2005	DIM(Driver Information Module)																																
V Series(WAGONS)	V50	2005	DDM(Driver Door Module)																																
V Series(WAGONS)	V50	2005	PDM(Passenger Door Module)																																
V Series(WAGONS)	V50	2005	PSM(Power Seat Module)																																
V Series(WAGONS)	V50	2005	CCM(Climate Control Module)																																
V Series(WAGONS)	V50	2005	SWM(Steering Wheel Module)																																
V Series(WAGONS)	V50	2004	System Search																																
V Series(WAGONS)	V50	2004	ECM(Engine Control Module)																																
V Series(WAGONS)	V50	2004	TCM(Transmission Control Module)																																
V Series(WAGONS)	V50	2004	ABS(Anti-Lock Brake System)																																
V Series(WAGONS)	V50	2004	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V50	2004	CEM(Central Electrical Module)																																
V Series(WAGONS)	V50	2004	DIM(Driver Information Module)																																
V Series(WAGONS)	V50	2004	DDM(Driver Door Module)																																
V Series(WAGONS)	V50	2004	PDM(Passenger Door Module)																																
V Series(WAGONS)	V50	2004	PSM(Power Seat Module)																																
V Series(WAGONS)	V50	2004	CCM(Climate Control Module)																																
V Series(WAGONS)	V50	2004	SWM(Steering Wheel Module)																																
V Series(WAGONS)	V60	2014	System Search																																
V Series(WAGONS)	V60	2014	ECM(Engine Control Module)																																
V Series(WAGONS)	V60	2014	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V60	2014	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V60	2014	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V60	2014	BCM(Brake Control Module)																																
V Series(WAGONS)	V60	2014	PBM(Park Brake Module)																				V												

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
V Series(WAGONS)	V60	2014	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V60	2014	PSCM(Power Steering Control Module)																																
V Series(WAGONS)	V60	2014	FSM(Forward Sensing Module)																					V											
V Series(WAGONS)	V60	2014	CVM(Closing Velocity Module)																																
V Series(WAGONS)	V60	2014	DIM(Driver Information Module)																						V	V	V	V	V						
V Series(WAGONS)	V60	2014	SUM(SUspension Module)																																
V Series(WAGONS)	V60	2014	PAM(Parking Assistance Module)																											V					
V Series(WAGONS)	V60	2014	CEM(Central Electrical Module)																												V				
V Series(WAGONS)	V60	2014	ICM(Infotainment Control Module)																																
V Series(WAGONS)	V60	2014	PDM(Passenger door module)																													V	V		
V Series(WAGONS)	V60	2014	IAM(Integrated Audio Module)																																
V Series(WAGONS)	V60	2014	CCM(Climate control module)																																V
V Series(WAGONS)	V60	2014	AUD(AUdio Module)																																
V Series(WAGONS)	V60	2014	DDM(Driver Door Module)																													V	V		
V Series(WAGONS)	V60	2013	System Search																																
V Series(WAGONS)	V60	2013	ECM(Engine Control Module)																																
V Series(WAGONS)	V60	2013	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V60	2013	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V60	2013	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V60	2013	BCM(Brake Control Module)																																
V Series(WAGONS)	V60	2013	PBM(Park Brake Module)																				V												
V Series(WAGONS)	V60	2013	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V60	2013	PSCM(Power Steering Control Module)																																
V Series(WAGONS)	V60	2013	FSM(Forward Sensing Module)																					V											
V Series(WAGONS)	V60	2013	CVM(Closing Velocity Module)																																
V Series(WAGONS)	V60	2013	DIM(Driver Information Module)																						V	V	V	V	V						
V Series(WAGONS)	V60	2013	SUM(SUspension Module)																																
V Series(WAGONS)	V60	2013	PAM(Parking Assistance Module)																											V					
V Series(WAGONS)	V60	2013	CEM(Central Electrical Module)																												V				
V Series(WAGONS)	V60	2013	ICM(Infotainment Control Module)																																
V Series(WAGONS)	V60	2013	PDM(Passenger door module)																													V	V		
V Series(WAGONS)	V60	2013	IAM(Integrated Audio Module)																																
V Series(WAGONS)	V60	2013	CCM(Climate control module)																																V
V Series(WAGONS)	V60	2013	AUD(AUdio Module)																																
V Series(WAGONS)	V60	2013	DDM(Driver Door Module)																													V	V		
V Series(WAGONS)	V60	2012	System Search																																
V Series(WAGONS)	V60	2012	ECM(Engine Control Module)																																
V Series(WAGONS)	V60	2012	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V60	2012	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V60	2012	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V60	2012	BCM(Brake Control Module)																																
V Series(WAGONS)	V60	2012	PBM(Park Brake Module)																				V												
V Series(WAGONS)	V60	2012	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V60	2012	PSCM(Power Steering Control Module)																																
V Series(WAGONS)	V60	2012	FSM(Forward Sensing Module)																					V											
V Series(WAGONS)	V60	2012	CVM(Closing Velocity Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
V Series(WAGONS)	V60	2012	DIM(Driver Information Module)																						V	V	V	V	V						
V Series(WAGONS)	V60	2012	SUM(SUspension Module)																																
V Series(WAGONS)	V60	2012	PAM(Parking Assistance Module)																											V					
V Series(WAGONS)	V60	2012	CEM(Central Electrical Module)																												V				
V Series(WAGONS)	V60	2012	ICM(Infotainment Control Module)																																
V Series(WAGONS)	V60	2012	PDM(Passenger door module)																													V	V		
V Series(WAGONS)	V60	2012	IAM(Integrated Audio Module)																																
V Series(WAGONS)	V60	2012	CCM(Climate control module)																																V
V Series(WAGONS)	V60	2012	AUD(AUdio Module)																																
V Series(WAGONS)	V60	2012	DDM(Driver Door Module)																													V	V		
V Series(WAGONS)	V60	2011	System Search																																
V Series(WAGONS)	V60	2011	ECM(Engine Control Module)																																
V Series(WAGONS)	V60	2011	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V60	2011	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V60	2011	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V60	2011	BCM(Brake Control Module)																																
V Series(WAGONS)	V60	2011	PBM(Park Brake Module)																				V												
V Series(WAGONS)	V60	2011	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V60	2011	PSCM(Power Steering Control Module)																																
V Series(WAGONS)	V60	2011	FSM(Forward Sensing Module)																					V											
V Series(WAGONS)	V60	2011	CVM(Closing Velocity Module)																																
V Series(WAGONS)	V60	2011	DIM(Driver Information Module)																						V	V	V	V	V						
V Series(WAGONS)	V60	2011	SUM(SUspension Module)																																
V Series(WAGONS)	V60	2011	PAM(Parking Assistance Module)																											V					
V Series(WAGONS)	V60	2011	CEM(Central Electrical Module)																												V				
V Series(WAGONS)	V60	2011	ICM(Infotainment Control Module)																																
V Series(WAGONS)	V60	2011	PDM(Passenger door module)																													V	V		
V Series(WAGONS)	V60	2011	IAM(Integrated Audio Module)																																
V Series(WAGONS)	V60	2011	CCM(Climate control module)																																V
V Series(WAGONS)	V60	2011	AUD(AUdio Module)																																
V Series(WAGONS)	V60	2011	DDM(Driver Door Module)																													V	V		
V Series(WAGONS)	V60	2010	System Search																																
V Series(WAGONS)	V60	2010	ECM(Engine Control Module)																																
V Series(WAGONS)	V60	2010	TCM(Transmission Control Module)	TF-80SC																															
V Series(WAGONS)	V60	2010	TCM(Transmission Control Module)	TG-81SC																															
V Series(WAGONS)	V60	2010	SAS(Steering Angle Sensor module)																																
V Series(WAGONS)	V60	2010	BCM(Brake Control Module)																																
V Series(WAGONS)	V60	2010	PBM(Park Brake Module)																				V												
V Series(WAGONS)	V60	2010	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V60	2010	PSCM(Power Steering Control Module)																																
V Series(WAGONS)	V60	2010	FSM(Forward Sensing Module)																					V											
V Series(WAGONS)	V60	2010	CVM(Closing Velocity Module)																																
V Series(WAGONS)	V60	2010	DIM(Driver Information Module)																						V	V	V	V	V						
V Series(WAGONS)	V60	2010	SUM(SUspension Module)																																
V Series(WAGONS)	V60	2010	PAM(Parking Assistance Module)																											V					
V Series(WAGONS)	V60	2010	CEM(Central Electrical Module)																												V				

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
V Series(WAGONS)	V60	2010	ICM(Infotainment Control Module)																																
V Series(WAGONS)	V60	2010	PDM(Passenger door module)																													V	V		
V Series(WAGONS)	V60	2010	IAM(Integrated Audio Module)																																
V Series(WAGONS)	V60	2010	CCM(Climate control module)																																V
V Series(WAGONS)	V60	2010	AUD(AUdio Module)																																
V Series(WAGONS)	V60	2010	DDM(Driver Door Module)																													V	V		
V Series(WAGONS)	V70	2004~2007	System Search																																
V Series(WAGONS)	V70	2004~2007	ECM(Engine Control Module)		V	V	V	V	V	V																									
V Series(WAGONS)	V70	2004~2007	TCM(Transmission Control Module)																																
V Series(WAGONS)	V70	2004~2007	ABS(Anti-Lock Brake System)																																
V Series(WAGONS)	V70	2004~2007	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V70	2004~2007	CEM(Central Electrical Module)																																
V Series(WAGONS)	V70	2004~2007	DIM(Driver Information Module)																																
V Series(WAGONS)	V70	2004~2007	DDM(Driver Door Module)																																
V Series(WAGONS)	V70	2004~2007	PDM(Passenger Door Module)																																
V Series(WAGONS)	V70	2004~2007	PSM(Power Seat Module)																																
V Series(WAGONS)	V70	2004~2007	CCM(Climate Control Module)																																
V Series(WAGONS)	V70	2004~2007	SAS(Steering Wheel Angle Sensor Module)																																
V Series(WAGONS)	V70	2004~2007	UEM(Up Electrical Module)																																
V Series(WAGONS)	V70	2004~2007	REM(Rear Electrical Module)																																
V Series(WAGONS)	V70	2004~2007	AUM(Audio Module)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	System Search																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	ECM(Engine Control Module)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	TCM(Transmission Control Module)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	ABS(Anti-Lock Brake System)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	SRS(Supplemental Restraint System)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	CEM(Central Electrical Module)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	DIM(Driver Information Module)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	DDM(Driver Door Module)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	PDM(Passenger Door Module)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	PSM(Power Seat Module)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	CCM(Climate Control Module)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	SWM(Steering Wheel Module)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	UEM(Up Electrical Module)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	REM(Rear Electrical Module)																																
V Series(WAGONS)	V70	2000(New Model) ~ 2004	AUM(Audio Module)																																
V Series(WAGONS)	V70	1999~2000	System Search																																
V Series(WAGONS)	V70	1999~2000	ECM(Engine Control Module)																																
V Series(WAGONS)	V70	1999~2000	TCM(Transmission Control Module)																																
V Series(WAGONS)	V70	1999~2000	ABS(Anti-Lock Brake System)																																
V Series(WAGONS)	V70	1999~2000	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	Maintenance	0	BCM(Brake control module) Service function																																
XC Series(CROSSOVERS)	Maintenance	0	PBM(Parking brake module) Service function																																
XC Series(CROSSOVERS)	Maintenance	0	Service Reminder Reset																																
XC Series(CROSSOVERS)	Maintenance	0	Technical Information																																
XC Series(CROSSOVERS)	V70XC	2007	System Search																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	V70XC	2007	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	V70XC	2007	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	V70XC	2007	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	V70XC	2007	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	V70XC	2007	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2007	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	V70XC	2007	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	V70XC	2007	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	V70XC	2007	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	V70XC	2007	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	V70XC	2007	SAS(Steering Wheel Angle Sensor Module)																																
XC Series(CROSSOVERS)	V70XC	2007	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2007	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2007	AUM(Audio Module)																																
XC Series(CROSSOVERS)	V70XC	2006	System Search																																
XC Series(CROSSOVERS)	V70XC	2006	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	V70XC	2006	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	V70XC	2006	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	V70XC	2006	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	V70XC	2006	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2006	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	V70XC	2006	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	V70XC	2006	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	V70XC	2006	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	V70XC	2006	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	V70XC	2006	SAS(Steering Wheel Angle Sensor Module)																																
XC Series(CROSSOVERS)	V70XC	2006	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2006	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2006	AUM(Audio Module)																																
XC Series(CROSSOVERS)	V70XC	2005	System Search																																
XC Series(CROSSOVERS)	V70XC	2005	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	V70XC	2005	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	V70XC	2005	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	V70XC	2005	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	V70XC	2005	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2005	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	V70XC	2005	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	V70XC	2005	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	V70XC	2005	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	V70XC	2005	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	V70XC	2005	SAS(Steering Wheel Angle Sensor Module)																																
XC Series(CROSSOVERS)	V70XC	2005	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2005	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2005	AUM(Audio Module)																																
XC Series(CROSSOVERS)	V70XC	2004	System Search																																
XC Series(CROSSOVERS)	V70XC	2004	ECM(Engine Control Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	V70XC	2004	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	V70XC	2004	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	V70XC	2004	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	V70XC	2004	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2004	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	V70XC	2004	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	V70XC	2004	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	V70XC	2004	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	V70XC	2004	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	V70XC	2004	SWM(Steering Wheel Module)																																
XC Series(CROSSOVERS)	V70XC	2004	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2004	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2004	AUM(Audio Module)																																
XC Series(CROSSOVERS)	V70XC	2003	System Search																																
XC Series(CROSSOVERS)	V70XC	2003	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	V70XC	2003	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	V70XC	2003	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	V70XC	2003	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	V70XC	2003	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2003	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	V70XC	2003	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	V70XC	2003	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	V70XC	2003	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	V70XC	2003	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	V70XC	2003	SWM(Steering Wheel Module)																																
XC Series(CROSSOVERS)	V70XC	2003	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2003	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2003	AUM(Audio Module)																																
XC Series(CROSSOVERS)	V70XC	2002	System Search																																
XC Series(CROSSOVERS)	V70XC	2002	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	V70XC	2002	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	V70XC	2002	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	V70XC	2002	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	V70XC	2002	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2002	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	V70XC	2002	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	V70XC	2002	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	V70XC	2002	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	V70XC	2002	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	V70XC	2002	SWM(Steering Wheel Module)																																
XC Series(CROSSOVERS)	V70XC	2002	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2002	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2002	AUM(Audio Module)																																
XC Series(CROSSOVERS)	V70XC	2001	System Search																																
XC Series(CROSSOVERS)	V70XC	2001	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	V70XC	2001	TCM(Transmission Control Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	V70XC	2001	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	V70XC	2001	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	V70XC	2001	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2001	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	V70XC	2001	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	V70XC	2001	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	V70XC	2001	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	V70XC	2001	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	V70XC	2001	SWM(Steering Wheel Module)																																
XC Series(CROSSOVERS)	V70XC	2001	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2001	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2001	AUM(Audio Module)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	System Search																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	SWM(Steering Wheel Module)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	V70XC	2000(New Model)	AUM(Audio Module)																																
XC Series(CROSSOVERS)	V70XC	2000	System Search																																
XC Series(CROSSOVERS)	V70XC	2000	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	V70XC	2000	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	V70XC	2000	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	V70XC	1999	System Search																																
XC Series(CROSSOVERS)	V70XC	1999	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	V70XC	1999	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	V70XC	1999	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC60	2015	System Search																																
XC Series(CROSSOVERS)	XC60	2015	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC60	2015	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC60	2015	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC60	2015	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC60	2015	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC60	2015	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC60	2015	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC60	2015	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC60	2015	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC60	2015	CVM(Closing Velocity Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	XC60	2015	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC60	2015	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC60	2015	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC60	2015	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC60	2015	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC60	2015	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC60	2015	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC60	2015	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC60	2015	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC60	2015	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC60	2015	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC60	2015	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC60	2015	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC60	2015	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC60	2015	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC60	2014	System Search																																
XC Series(CROSSOVERS)	XC60	2014	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC60	2014	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC60	2014	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC60	2014	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC60	2014	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC60	2014	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC60	2014	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC60	2014	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC60	2014	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC60	2014	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC60	2014	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC60	2014	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC60	2014	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC60	2014	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC60	2014	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC60	2014	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC60	2014	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC60	2014	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC60	2014	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC60	2014	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC60	2014	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC60	2014	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC60	2014	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC60	2014	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC60	2014	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC60	2013	System Search																																
XC Series(CROSSOVERS)	XC60	2013	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC60	2013	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC60	2013	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC60	2013	SAS(Steering Angle Sensor module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	XC60	2013	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC60	2013	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC60	2013	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC60	2013	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC60	2013	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC60	2013	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC60	2013	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC60	2013	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC60	2013	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC60	2013	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC60	2013	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC60	2013	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC60	2013	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC60	2013	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC60	2013	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC60	2013	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC60	2013	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC60	2013	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC60	2013	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC60	2013	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC60	2013	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC60	2012	System Search																																
XC Series(CROSSOVERS)	XC60	2012	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC60	2012	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC60	2012	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC60	2012	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC60	2012	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC60	2012	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC60	2012	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC60	2012	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC60	2012	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC60	2012	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC60	2012	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC60	2012	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC60	2012	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC60	2012	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC60	2012	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC60	2012	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC60	2012	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC60	2012	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC60	2012	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC60	2012	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC60	2012	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC60	2012	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC60	2012	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC60	2012	RDAR(Remote Digital Audio Receiver)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	XC60	2012	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC60	2011	System Search																																
XC Series(CROSSOVERS)	XC60	2011	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC60	2011	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC60	2011	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC60	2011	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC60	2011	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC60	2011	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC60	2011	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC60	2011	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC60	2011	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC60	2011	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC60	2011	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC60	2011	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC60	2011	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC60	2011	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC60	2011	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC60	2011	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC60	2011	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC60	2011	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC60	2011	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC60	2011	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC60	2011	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC60	2011	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC60	2011	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC60	2011	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC60	2011	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC60	2010	System Search																																
XC Series(CROSSOVERS)	XC60	2010	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC60	2010	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC60	2010	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC60	2010	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC60	2010	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC60	2010	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC60	2010	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC60	2010	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC60	2010	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC60	2010	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC60	2010	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC60	2010	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC60	2010	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC60	2010	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC60	2010	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC60	2010	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC60	2010	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC60	2010	DDM(Driver Door Module)																													V	V		

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	XC60	2010	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC60	2010	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC60	2010	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC60	2010	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC60	2010	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC60	2010	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC60	2010	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC70	2015	System Search																																
XC Series(CROSSOVERS)	XC70	2015	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2015	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC70	2015	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC70	2015	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC70	2015	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC70	2015	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC70	2015	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2015	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC70	2015	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC70	2015	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC70	2015	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC70	2015	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC70	2015	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC70	2015	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC70	2015	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC70	2015	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC70	2015	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC70	2015	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC70	2015	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2015	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC70	2015	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC70	2015	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC70	2015	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC70	2015	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC70	2015	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC70	2014	System Search																																
XC Series(CROSSOVERS)	XC70	2014	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2014	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC70	2014	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC70	2014	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC70	2014	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC70	2014	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC70	2014	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2014	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC70	2014	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC70	2014	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC70	2014	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC70	2014	PAM(Parking Assistance Module)																											V					

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	XC70	2014	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC70	2014	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC70	2014	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC70	2014	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC70	2014	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC70	2014	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC70	2014	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2014	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC70	2014	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC70	2014	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC70	2014	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC70	2014	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC70	2014	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC70	2013	System Search																																
XC Series(CROSSOVERS)	XC70	2013	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2013	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC70	2013	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC70	2013	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC70	2013	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC70	2013	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC70	2013	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2013	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC70	2013	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC70	2013	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC70	2013	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC70	2013	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC70	2013	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC70	2013	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC70	2013	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC70	2013	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC70	2013	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC70	2013	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC70	2013	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2013	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC70	2013	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC70	2013	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC70	2013	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC70	2013	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC70	2013	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC70	2012	System Search																																
XC Series(CROSSOVERS)	XC70	2012	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2012	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC70	2012	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC70	2012	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC70	2012	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC70	2012	PBM(Park Brake Module)																				V												

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	XC70	2012	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2012	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC70	2012	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC70	2012	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC70	2012	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC70	2012	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC70	2012	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC70	2012	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC70	2012	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC70	2012	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC70	2012	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC70	2012	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC70	2012	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2012	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC70	2012	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC70	2012	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC70	2012	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC70	2012	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC70	2012	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC70	2011	System Search																																
XC Series(CROSSOVERS)	XC70	2011	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2011	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC70	2011	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC70	2011	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC70	2011	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC70	2011	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC70	2011	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2011	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC70	2011	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC70	2011	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC70	2011	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC70	2011	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC70	2011	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC70	2011	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC70	2011	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC70	2011	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC70	2011	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC70	2011	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC70	2011	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2011	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC70	2011	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC70	2011	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC70	2011	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC70	2011	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC70	2011	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC70	2010	System Search																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	XC70	2010	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2010	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC70	2010	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC70	2010	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC70	2010	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC70	2010	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC70	2010	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2010	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC70	2010	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC70	2010	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC70	2010	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC70	2010	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC70	2010	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC70	2010	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC70	2010	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC70	2010	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC70	2010	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC70	2010	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC70	2010	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2010	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC70	2010	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC70	2010	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC70	2010	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC70	2010	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC70	2010	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC70	2009	System Search																																
XC Series(CROSSOVERS)	XC70	2009	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2009	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC70	2009	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC70	2009	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC70	2009	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC70	2009	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC70	2009	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2009	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC70	2009	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC70	2009	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC70	2009	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC70	2009	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC70	2009	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC70	2009	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC70	2009	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC70	2009	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC70	2009	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC70	2009	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC70	2009	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2009	DEM(Differential Electronic Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	XC70	2009	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC70	2009	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC70	2009	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC70	2009	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC70	2009	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC70	2008	System Search																																
XC Series(CROSSOVERS)	XC70	2008	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2008	TCM(Transmission Control Module)	TF-80SC																															
XC Series(CROSSOVERS)	XC70	2008	TCM(Transmission Control Module)	TG-81SC																															
XC Series(CROSSOVERS)	XC70	2008	SAS(Steering Angle Sensor module)																																
XC Series(CROSSOVERS)	XC70	2008	BCM(Brake Control Module)																																
XC Series(CROSSOVERS)	XC70	2008	PBM(Park Brake Module)																				V												
XC Series(CROSSOVERS)	XC70	2008	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2008	PSCM(Power Steering Control Module)																																
XC Series(CROSSOVERS)	XC70	2008	FSM(Forward Sensing Module)																					V											
XC Series(CROSSOVERS)	XC70	2008	CVM(Closing Velocity Module)																																
XC Series(CROSSOVERS)	XC70	2008	DIM(Driver Information Module)																						V	V	V	V	V						
XC Series(CROSSOVERS)	XC70	2008	PAM(Parking Assistance Module)																											V					
XC Series(CROSSOVERS)	XC70	2008	CEM(Central Electrical Module)																												V				
XC Series(CROSSOVERS)	XC70	2008	ICM(Infotainment Control Module)																																
XC Series(CROSSOVERS)	XC70	2008	PDM(Passenger door module)																													V	V		
XC Series(CROSSOVERS)	XC70	2008	CCM(Climate control module)																																
XC Series(CROSSOVERS)	XC70	2008	AUD(AUdio Module)																																
XC Series(CROSSOVERS)	XC70	2008	DDM(Driver Door Module)																													V	V		
XC Series(CROSSOVERS)	XC70	2008	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2008	DEM(Differential Electronic Module)																																
XC Series(CROSSOVERS)	XC70	2008	POT(Power operated tailgate module)																																
XC Series(CROSSOVERS)	XC70	2008	SODR(Side Obstacle Detection control module Right)																																
XC Series(CROSSOVERS)	XC70	2008	SODL(Side Obstacle Detection control module Left)																																
XC Series(CROSSOVERS)	XC70	2008	RDAR(Remote Digital Audio Receiver)																																
XC Series(CROSSOVERS)	XC70	2008	BPM(Bluetooth phone module)																																
XC Series(CROSSOVERS)	XC70	2007	System Search																																
XC Series(CROSSOVERS)	XC70	2007	ECM(Engine Control Module)		V	V	V	V	V	V																									
XC Series(CROSSOVERS)	XC70	2007	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	XC70	2007	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC70	2007	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2007	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2007	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	XC70	2007	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	XC70	2007	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	XC70	2007	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2007	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	XC70	2007	SAS(Steering Wheel Angle Sensor Module)																																
XC Series(CROSSOVERS)	XC70	2007	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2007	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2007	AUM(Audio Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	XC70	2006	System Search																																
XC Series(CROSSOVERS)	XC70	2006	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2006	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	XC70	2006	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC70	2006	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2006	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2006	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	XC70	2006	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	XC70	2006	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	XC70	2006	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2006	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	XC70	2006	SAS(Steering Wheel Angle Sensor Module)																																
XC Series(CROSSOVERS)	XC70	2006	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2006	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2006	AUM(Audio Module)																																
XC Series(CROSSOVERS)	XC70	2005	System Search																																
XC Series(CROSSOVERS)	XC70	2005	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2005	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	XC70	2005	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC70	2005	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2005	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2005	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	XC70	2005	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	XC70	2005	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	XC70	2005	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2005	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	XC70	2005	SAS(Steering Wheel Angle Sensor Module)																																
XC Series(CROSSOVERS)	XC70	2005	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2005	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2005	AUM(Audio Module)																																
XC Series(CROSSOVERS)	XC70	2004	System Search																																
XC Series(CROSSOVERS)	XC70	2004	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2004	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	XC70	2004	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC70	2004	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2004	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2004	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	XC70	2004	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	XC70	2004	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	XC70	2004	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2004	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	XC70	2004	SWM(Steering Wheel Module)																																
XC Series(CROSSOVERS)	XC70	2004	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2004	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2004	AUM(Audio Module)																																
XC Series(CROSSOVERS)	XC70	2003	System Search																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	XC70	2003	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2003	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	XC70	2003	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC70	2003	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2003	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2003	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	XC70	2003	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	XC70	2003	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	XC70	2003	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2003	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	XC70	2003	SWM(Steering Wheel Module)																																
XC Series(CROSSOVERS)	XC70	2003	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2003	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2003	AUM(Audio Module)																																
XC Series(CROSSOVERS)	XC70	2002	System Search																																
XC Series(CROSSOVERS)	XC70	2002	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2002	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	XC70	2002	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC70	2002	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2002	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2002	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	XC70	2002	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	XC70	2002	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	XC70	2002	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2002	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	XC70	2002	SWM(Steering Wheel Module)																																
XC Series(CROSSOVERS)	XC70	2002	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2002	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2002	AUM(Audio Module)																																
XC Series(CROSSOVERS)	XC70	2001	System Search																																
XC Series(CROSSOVERS)	XC70	2001	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC70	2001	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	XC70	2001	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC70	2001	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC70	2001	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2001	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	XC70	2001	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	XC70	2001	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	XC70	2001	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC70	2001	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	XC70	2001	SWM(Steering Wheel Module)																																
XC Series(CROSSOVERS)	XC70	2001	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2001	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	XC70	2001	AUM(Audio Module)																																
XC Series(CROSSOVERS)	XC90	2007	System Search																																
XC Series(CROSSOVERS)	XC90	2007	ECM(Engine Control Module)		V	V	V	V	V	V																									

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	XC90	2007	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	XC90	2007	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC90	2007	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC90	2007	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2007	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	XC90	2007	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	XC90	2007	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	XC90	2007	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC90	2007	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	XC90	2007	SAS(Steering Wheel Angle Sensor Module)																																
XC Series(CROSSOVERS)	XC90	2007	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2007	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2006	System Search																																
XC Series(CROSSOVERS)	XC90	2006	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC90	2006	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	XC90	2006	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC90	2006	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC90	2006	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2006	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	XC90	2006	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	XC90	2006	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	XC90	2006	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC90	2006	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	XC90	2006	SAS(Steering Wheel Angle Sensor Module)																																
XC Series(CROSSOVERS)	XC90	2006	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2006	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2005	System Search																																
XC Series(CROSSOVERS)	XC90	2005	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC90	2005	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	XC90	2005	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC90	2005	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC90	2005	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2005	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	XC90	2005	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	XC90	2005	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	XC90	2005	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC90	2005	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	XC90	2005	SAS(Steering Wheel Angle Sensor Module)																																
XC Series(CROSSOVERS)	XC90	2005	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2005	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2004	System Search																																
XC Series(CROSSOVERS)	XC90	2004	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC90	2004	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	XC90	2004	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC90	2004	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC90	2004	CEM(Central Electrical Module)																																

Series	Vehicle	Year	System 1	System 2	Adaptation of turbo control motor	Adaptation of heated oxygen sensor	Adaptation of mass airflow sensor	Adaptation of differential pressure sensor particle filter	Adaptation of fuel pressure control valve	Resetting counter particle filter	Calibration of position sensor	Resetting the counter for transmission oil change	Activation of adaption	Activating Test Mode	Calibration(only vehicles with DSTC)	Programming control module	Resetting low voltage counters	Resetting crash mode	Programming of short flash sequence	Programming the infotainment control module(ICM)	Programming Afterrun	Programming the clock	Activation and service	Calibration of radar and camera	Testing all indicators and lamps in the DIM	Display of vehicle speed	Programming the seat memory's delay time and acknowledgement	Programming seatbelt reminder in backseat	Programming text message+ seatbelt reminder	Programming of Parking Assistance Module (PAM)	Programming of rear window wiper when reversing	Initializing the window in the front door	Initializing the window in the rear door	Reinstalling the reserve battery	Calibrating the climate control module (CCM)
XC Series(CROSSOVERS)	XC90	2004	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	XC90	2004	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	XC90	2004	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	XC90	2004	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC90	2004	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	XC90	2004	SWM(Steering Wheel Module)																																
XC Series(CROSSOVERS)	XC90	2004	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2004	REM(Rear Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2003	System Search																																
XC Series(CROSSOVERS)	XC90	2003	ECM(Engine Control Module)																																
XC Series(CROSSOVERS)	XC90	2003	TCM(Transmission Control Module)																																
XC Series(CROSSOVERS)	XC90	2003	ABS(Anti-Lock Brake System)																																
XC Series(CROSSOVERS)	XC90	2003	SRS(Supplemental Restraint System)																																
XC Series(CROSSOVERS)	XC90	2003	CEM(Central Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2003	DIM(Driver Information Module)																																
XC Series(CROSSOVERS)	XC90	2003	DDM(Driver Door Module)																																
XC Series(CROSSOVERS)	XC90	2003	PDM(Passenger Door Module)																																
XC Series(CROSSOVERS)	XC90	2003	PSM(Power Seat Module)																																
XC Series(CROSSOVERS)	XC90	2003	CCM(Climate Control Module)																																
XC Series(CROSSOVERS)	XC90	2003	SWM(Steering Wheel Module)																																
XC Series(CROSSOVERS)	XC90	2003	UEM(Up Electrical Module)																																
XC Series(CROSSOVERS)	XC90	2003	REM(Rear Electrical Module)																																

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
C Series(COUPES)	Maintenance		BCM(Brake control module) Service function																	
C Series(COUPES)	Maintenance		PBM(Parking brake module) Service function																	
C Series(COUPES)	Maintenance		Service Reminder Reset																	
C Series(COUPES)	Maintenance		Technical Information																	
C Series(COUPES)	C30	2012	System Search																	
C Series(COUPES)	C30	2012	ECM(Engine Control Module)																	
C Series(COUPES)	C30	2012	TCM(Transmission Control Module)	TF-80SC																
C Series(COUPES)	C30	2012	TCM(Transmission Control Module)	TG-81SC																
C Series(COUPES)	C30	2012	SAS(Steering Angle Sensor module)																	
C Series(COUPES)	C30	2012	BCM(Brake Control Module)																	
C Series(COUPES)	C30	2012	SRS(Supplemental Restraint System)																	
C Series(COUPES)	C30	2012	DIM(Driver Information Module)																	
C Series(COUPES)	C30	2012	CEM(Central Electrical Module)																	
C Series(COUPES)	C30	2012	PDM(Passenger door module)																	
C Series(COUPES)	C30	2012	DDM(Driver door module)																	
C Series(COUPES)	C30	2012	EPS(Electrical power steering module)																	
C Series(COUPES)	C30	2012	HCM(Headlamp control module)																	
C Series(COUPES)	C30	2011	System Search																	
C Series(COUPES)	C30	2011	ECM(Engine Control Module)																	
C Series(COUPES)	C30	2011	TCM(Transmission Control Module)	TF-80SC																
C Series(COUPES)	C30	2011	TCM(Transmission Control Module)	TG-81SC																
C Series(COUPES)	C30	2011	SAS(Steering Angle Sensor module)																	
C Series(COUPES)	C30	2011	BCM(Brake Control Module)																	
C Series(COUPES)	C30	2011	SRS(Supplemental Restraint System)																	
C Series(COUPES)	C30	2011	DIM(Driver Information Module)																	
C Series(COUPES)	C30	2011	CEM(Central Electrical Module)																	
C Series(COUPES)	C30	2011	PDM(Passenger door module)																	
C Series(COUPES)	C30	2011	DDM(Driver door module)																	
C Series(COUPES)	C30	2011	EPS(Electrical power steering module)																	
C Series(COUPES)	C30	2011	HCM(Headlamp control module)																	
C Series(COUPES)	C30	2010	System Search																	
C Series(COUPES)	C30	2010	ECM(Engine Control Module)																	
C Series(COUPES)	C30	2010	TCM(Transmission Control Module)	TF-80SC																
C Series(COUPES)	C30	2010	TCM(Transmission Control Module)	TG-81SC																
C Series(COUPES)	C30	2010	ABS(Anti-Lock Brake System)																	
C Series(COUPES)	C30	2010	SAS(Steering Angle Sensor module)																	
C Series(COUPES)	C30	2010	BCM(Brake Control Module)																	
C Series(COUPES)	C30	2010	SRS(Supplemental Restraint System)																	
C Series(COUPES)	C30	2010	DIM(Driver Information Module)																	
C Series(COUPES)	C30	2010	CEM(Central Electrical Module)																	
C Series(COUPES)	C30	2010	PDM(Passenger door module)																	
C Series(COUPES)	C30	2010	DDM(Driver door module)																	
C Series(COUPES)	C30	2010	PSM(Power Seat Module)																	
C Series(COUPES)	C30	2010	CCM(Climate Control Module)																	
C Series(COUPES)	C30	2010	EPS(Electrical power steering module)																	
C Series(COUPES)	C30	2010	SWM(Steering Wheel Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
C Series(COUPES)	C30	2010	HCM(Headlamp control module)																	
C Series(COUPES)	C30	2009	System Search																	
C Series(COUPES)	C30	2009	ECM(Engine Control Module)																	
C Series(COUPES)	C30	2009	TCM(Transmission Control Module)	TF-80SC																
C Series(COUPES)	C30	2009	TCM(Transmission Control Module)	TG-81SC																
C Series(COUPES)	C30	2009	ABS(Anti-Lock Brake System)																	
C Series(COUPES)	C30	2009	SAS(Steering Angle Sensor module)																	
C Series(COUPES)	C30	2009	BCM(Brake Control Module)																	
C Series(COUPES)	C30	2009	SRS(Supplemental Restraint System)																	
C Series(COUPES)	C30	2009	DIM(Driver Information Module)																	
C Series(COUPES)	C30	2009	CEM(Central Electrical Module)																	
C Series(COUPES)	C30	2009	PDM(Passenger door module)																	
C Series(COUPES)	C30	2009	DDM(Driver door module)																	
C Series(COUPES)	C30	2009	PSM(Power Seat Module)																	
C Series(COUPES)	C30	2009	CCM(Climate Control Module)																	
C Series(COUPES)	C30	2009	EPS(Electrical power steering module)																	
C Series(COUPES)	C30	2009	SWM(Steering Wheel Module)																	
C Series(COUPES)	C30	2009	HCM(Headlamp control module)																	
C Series(COUPES)	C30	2008	System Search																	
C Series(COUPES)	C30	2008	ECM(Engine Control Module)																	
C Series(COUPES)	C30	2008	TCM(Transmission Control Module)	TF-80SC																
C Series(COUPES)	C30	2008	TCM(Transmission Control Module)	AW55-50 - 51 SN																
C Series(COUPES)	C30	2008	ABS(Anti-Lock Brake System)																	
C Series(COUPES)	C30	2008	SRS(Supplemental Restraint System)																	
C Series(COUPES)	C30	2008	DIM(Driver Information Module)																	
C Series(COUPES)	C30	2008	PAM(Parking Assistance Module)																	
C Series(COUPES)	C30	2008	CEM(Central Electrical Module)																	
C Series(COUPES)	C30	2008	ICM(Infotainment Control Module)																	
C Series(COUPES)	C30	2008	PDM(Passenger Door Module)																	
C Series(COUPES)	C30	2008	IAM(Integrated Audio Module)																	
C Series(COUPES)	C30	2008	CCM(Climate Control Module)																	
C Series(COUPES)	C30	2008	AUD(AUdio Module)																	
C Series(COUPES)	C30	2008	DDM(Driver Door Module)																	
C Series(COUPES)	C30	2008	PSM(Power Seat Module)																	
C Series(COUPES)	C30	2008	SWM(Steering Wheel Module)																	
C Series(COUPES)	C30	2007	System Search																	
C Series(COUPES)	C30	2007	ECM(Engine Control Module)																	
C Series(COUPES)	C30	2007	TCM(Transmission Control Module)																	
C Series(COUPES)	C30	2007	ABS(Anti-Lock Brake System)																	
C Series(COUPES)	C30	2007	SRS(Supplemental Restraint System)																	
C Series(COUPES)	C30	2007	CEM(Central Electrical Module)																	
C Series(COUPES)	C30	2007	DIM(Driver Information Module)																	
C Series(COUPES)	C30	2007	DDM(Driver Door Module)																	
C Series(COUPES)	C30	2007	PDM(Passenger Door Module)																	
C Series(COUPES)	C30	2007	PSM(Power Seat Module)																	
C Series(COUPES)	C30	2007	CCM(Climate Control Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 ~13w46)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
C Series(COUPES)	C30	2007	SWM(Steering Wheel Module)																	
C Series(COUPES)	C70	C70 Convertible	2007	System Search																
C Series(COUPES)	C70	C70 Convertible	2007	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Convertible	2007	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Convertible	2007	ABS(Anti-Lock Brake System)																
C Series(COUPES)	C70	C70 Convertible	2007	SRS(Supplemental Restraint System)																
C Series(COUPES)	C70	C70 Convertible	2007	CEM(Central Electrical Module)																
C Series(COUPES)	C70	C70 Convertible	2007	DIM(Driver Information Module)																
C Series(COUPES)	C70	C70 Convertible	2007	DDM(Driver Door Module)																
C Series(COUPES)	C70	C70 Convertible	2007	PDM(Passenger Door Module)																
C Series(COUPES)	C70	C70 Convertible	2007	PSM(Power Seat Module)																
C Series(COUPES)	C70	C70 Convertible	2007	CCM(Climate Control Module)																
C Series(COUPES)	C70	C70 Convertible	2007	SWM(Steering Wheel Module)																
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	System Search																
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	ABS(Anti-Lock Brake System)																
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	SRS(Supplemental Restraint System)																
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	CEM(Central Electrical Module)																
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	DIM(Driver Information Module)																
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	DDM(Driver Door Module)																
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	PDM(Passenger Door Module)																
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	PSM(Power Seat Module)																
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	CCM(Climate Control Module)																
C Series(COUPES)	C70	C70 Convertible	2006(New Model)	SWM(Steering Wheel Module)																
C Series(COUPES)	C70	C70 Convertible	2005	System Search																
C Series(COUPES)	C70	C70 Convertible	2005	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Convertible	2005	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Convertible	2005	ABS(Anti-Lock Brake System)																
C Series(COUPES)	C70	C70 Convertible	2004	System Search																
C Series(COUPES)	C70	C70 Convertible	2004	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Convertible	2004	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Convertible	2004	ABS(Anti-Lock Brake System)																
C Series(COUPES)	C70	C70 Convertible	2003	System Search																
C Series(COUPES)	C70	C70 Convertible	2003	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Convertible	2003	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Convertible	2003	ABS(Anti-Lock Brake System)																
C Series(COUPES)	C70	C70 Convertible	2002	System Search																
C Series(COUPES)	C70	C70 Convertible	2002	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Convertible	2002	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Convertible	2002	ABS(Anti-Lock Brake System)																
C Series(COUPES)	C70	C70 Convertible	2001	System Search																
C Series(COUPES)	C70	C70 Convertible	2001	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Convertible	2001	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Convertible	2001	ABS(Anti-Lock Brake System)																
C Series(COUPES)	C70	C70 Convertible	2000	System Search																

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
C Series(COUPES)	C70	C70 Convertible	2000	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Convertible	2000	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Convertible	2000	ABS(Anti-Lock Brake System)																
C Series(COUPES)	C70	C70 Convertible	1999	System Search																
C Series(COUPES)	C70	C70 Convertible	1999	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Convertible	1999	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Convertible	1999	ABS(Anti-Lock Brake System)																
C Series(COUPES)	C70	C70 Coupe	2002	System Search																
C Series(COUPES)	C70	C70 Coupe	2002	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Coupe	2002	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Coupe	2002	ABS(Anti-Lock Brake System)																
C Series(COUPES)	C70	C70 Coupe	2001	System Search																
C Series(COUPES)	C70	C70 Coupe	2001	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Coupe	2001	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Coupe	2001	ABS(Anti-Lock Brake System)																
C Series(COUPES)	C70	C70 Coupe	2000	System Search																
C Series(COUPES)	C70	C70 Coupe	2000	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Coupe	2000	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Coupe	2000	ABS(Anti-Lock Brake System)																
C Series(COUPES)	C70	C70 Coupe	1999	System Search																
C Series(COUPES)	C70	C70 Coupe	1999	ECM(Engine Control Module)																
C Series(COUPES)	C70	C70 Coupe	1999	TCM(Transmission Control Module)																
C Series(COUPES)	C70	C70 Coupe	1999	ABS(Anti-Lock Brake System)																
S Series(SEDANS)	Maintenance	BCM(Brake control module) Service function																		
S Series(SEDANS)	Maintenance	PBM(Parking brake module) Service function																		
S Series(SEDANS)	Maintenance	Service Reminder Reset																		
S Series(SEDANS)	Maintenance	Technical Information																		
S Series(SEDANS)	S40	2008	System Search																	
S Series(SEDANS)	S40	2008	ECM(Engine Control Module)																	
S Series(SEDANS)	S40	2008	TCM(Transmission Control Module)																	
S Series(SEDANS)	S40	2008	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S40	2008	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S40	2008	CEM(Central Electrical Module)																	
S Series(SEDANS)	S40	2008	DIM(Driver Information Module)																	
S Series(SEDANS)	S40	2008	DDM(Driver Door Module)																	
S Series(SEDANS)	S40	2008	PDM(Passenger Door Module)																	
S Series(SEDANS)	S40	2008	PSM(Power Seat Module)																	
S Series(SEDANS)	S40	2008	CCM(Climate Control Module)																	
S Series(SEDANS)	S40	2008	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S40	2007	System Search																	
S Series(SEDANS)	S40	2007	ECM(Engine Control Module)																	
S Series(SEDANS)	S40	2007	TCM(Transmission Control Module)																	
S Series(SEDANS)	S40	2007	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S40	2007	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S40	2007	CEM(Central Electrical Module)																	
S Series(SEDANS)	S40	2007	DIM(Driver Information Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S40	2007	DDM(Driver Door Module)																	
S Series(SEDANS)	S40	2007	PDM(Passenger Door Module)																	
S Series(SEDANS)	S40	2007	PSM(Power Seat Module)																	
S Series(SEDANS)	S40	2007	CCM(Climate Control Module)																	
S Series(SEDANS)	S40	2007	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S40	2006	System Search																	
S Series(SEDANS)	S40	2006	ECM(Engine Control Module)																	
S Series(SEDANS)	S40	2006	TCM(Transmission Control Module)																	
S Series(SEDANS)	S40	2006	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S40	2006	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S40	2006	CEM(Central Electrical Module)																	
S Series(SEDANS)	S40	2006	DIM(Driver Information Module)																	
S Series(SEDANS)	S40	2006	DDM(Driver Door Module)																	
S Series(SEDANS)	S40	2006	PDM(Passenger Door Module)																	
S Series(SEDANS)	S40	2006	PSM(Power Seat Module)																	
S Series(SEDANS)	S40	2006	CCM(Climate Control Module)																	
S Series(SEDANS)	S40	2006	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S40	2005	System Search																	
S Series(SEDANS)	S40	2005	ECM(Engine Control Module)																	
S Series(SEDANS)	S40	2005	TCM(Transmission Control Module)																	
S Series(SEDANS)	S40	2005	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S40	2005	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S40	2005	CEM(Central Electrical Module)																	
S Series(SEDANS)	S40	2005	DIM(Driver Information Module)																	
S Series(SEDANS)	S40	2005	DDM(Driver Door Module)																	
S Series(SEDANS)	S40	2005	PDM(Passenger Door Module)																	
S Series(SEDANS)	S40	2005	PSM(Power Seat Module)																	
S Series(SEDANS)	S40	2005	CCM(Climate Control Module)																	
S Series(SEDANS)	S40	2005	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S40	2004(New Model)	System Search																	
S Series(SEDANS)	S40	2004(New Model)	ECM(Engine Control Module)																	
S Series(SEDANS)	S40	2004(New Model)	TCM(Transmission Control Module)																	
S Series(SEDANS)	S40	2004(New Model)	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S40	2004(New Model)	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S40	2004(New Model)	CEM(Central Electrical Module)																	
S Series(SEDANS)	S40	2004(New Model)	DIM(Driver Information Module)																	
S Series(SEDANS)	S40	2004(New Model)	DDM(Driver Door Module)																	
S Series(SEDANS)	S40	2004(New Model)	PDM(Passenger Door Module)																	
S Series(SEDANS)	S40	2004(New Model)	PSM(Power Seat Module)																	
S Series(SEDANS)	S40	2004(New Model)	CCM(Climate Control Module)																	
S Series(SEDANS)	S40	2004(New Model)	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S60	2015	System Search																	
S Series(SEDANS)	S60	2015	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2015	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S60	2015	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S60	2015	SAS(Steering Angle Sensor module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S60	2015	BCM(Brake Control Module)																	
S Series(SEDANS)	S60	2015	PBM(Park Brake Module)																	
S Series(SEDANS)	S60	2015	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2015	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S60	2015	FSM(Forward Sensing Module)																	
S Series(SEDANS)	S60	2015	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S60	2015	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2015	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S60	2015	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2015	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S60	2015	PDM(Passenger door module)																	
S Series(SEDANS)	S60	2015	PHM(PHone Module)																	
S Series(SEDANS)	S60	2015	IAM(Integrated Audio Module)																	
S Series(SEDANS)	S60	2015	CCM(Climate control module)		V	V														
S Series(SEDANS)	S60	2015	AUD(AUdio Module)																	
S Series(SEDANS)	S60	2015	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2015	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2015	RDAR(Remote Digital Audio Receiver)																	
S Series(SEDANS)	S60	2015	KVM(Keyless Vehicle Module)				V	V	V	V	V									
S Series(SEDANS)	S60	2015	PAC(Parking Assistance Camera)									V	V							
S Series(SEDANS)	S60	2015	SODR(Side Obstacle Detection control module Right)																	
S Series(SEDANS)	S60	2015	SODL(Side Obstacle Detection control module Left)																	
S Series(SEDANS)	S60	2014	System Search																	
S Series(SEDANS)	S60	2014	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2014	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S60	2014	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S60	2014	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S60	2014	BCM(Brake Control Module)																	
S Series(SEDANS)	S60	2014	PBM(Park Brake Module)																	
S Series(SEDANS)	S60	2014	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2014	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S60	2014	FSM(Forward Sensing Module)																	
S Series(SEDANS)	S60	2014	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S60	2014	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2014	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S60	2014	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2014	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S60	2014	PDM(Passenger door module)																	
S Series(SEDANS)	S60	2014	PHM(PHone Module)																	
S Series(SEDANS)	S60	2014	IAM(Integrated Audio Module)																	
S Series(SEDANS)	S60	2014	CCM(Climate control module)		V	V														
S Series(SEDANS)	S60	2014	AUD(AUdio Module)																	
S Series(SEDANS)	S60	2014	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2014	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2014	RDAR(Remote Digital Audio Receiver)																	
S Series(SEDANS)	S60	2014	KVM(Keyless Vehicle Module)				V	V	V	V	V									

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S60	2014	PAC(Parking Assistance Camera)									V	V							
S Series(SEDANS)	S60	2014	SODR(Side Obstacle Detection control module Right)																	
S Series(SEDANS)	S60	2014	SODL(Side Obstacle Detection control module Left)																	
S Series(SEDANS)	S60	2013	System Search																	
S Series(SEDANS)	S60	2013	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2013	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S60	2013	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S60	2013	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S60	2013	BCM(Brake Control Module)																	
S Series(SEDANS)	S60	2013	PBM(Park Brake Module)																	
S Series(SEDANS)	S60	2013	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2013	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S60	2013	FSM(Forward Sensing Module)																	
S Series(SEDANS)	S60	2013	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S60	2013	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2013	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S60	2013	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2013	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S60	2013	PDM(Passenger door module)																	
S Series(SEDANS)	S60	2013	PHM(PHone Module)																	
S Series(SEDANS)	S60	2013	IAM(Integrated Audio Module)																	
S Series(SEDANS)	S60	2013	CCM(Climate control module)		V	V														
S Series(SEDANS)	S60	2013	AUD(AUdio Module)																	
S Series(SEDANS)	S60	2013	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2013	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2013	RDAR(Remote Digital Audio Receiver)																	
S Series(SEDANS)	S60	2013	KVM(Keyless Vehicle Module)				V	V	V	V	V									
S Series(SEDANS)	S60	2013	PAC(Parking Assistance Camera)									V	V							
S Series(SEDANS)	S60	2013	SODR(Side Obstacle Detection control module Right)																	
S Series(SEDANS)	S60	2013	SODL(Side Obstacle Detection control module Left)																	
S Series(SEDANS)	S60	2012	System Search																	
S Series(SEDANS)	S60	2012	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2012	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S60	2012	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S60	2012	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S60	2012	BCM(Brake Control Module)																	
S Series(SEDANS)	S60	2012	PBM(Park Brake Module)																	
S Series(SEDANS)	S60	2012	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2012	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S60	2012	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S60	2012	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2012	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S60	2012	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2012	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S60	2012	PDM(Passenger door module)																	
S Series(SEDANS)	S60	2012	IAM(Integrated Audio Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S60	2012	CCM(Climate control module)		V	V														
S Series(SEDANS)	S60	2012	AUD(AUdio Module)																	
S Series(SEDANS)	S60	2012	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2012	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2012	KVM(Keyless Vehicle Module)				V	V	V	V	V									
S Series(SEDANS)	S60	2011	System Search																	
S Series(SEDANS)	S60	2011	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2011	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S60	2011	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S60	2011	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S60	2011	BCM(Brake Control Module)																	
S Series(SEDANS)	S60	2011	PBM(Park Brake Module)																	
S Series(SEDANS)	S60	2011	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2011	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S60	2011	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S60	2011	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2011	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S60	2011	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2011	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S60	2011	PDM(Passenger door module)																	
S Series(SEDANS)	S60	2011	IAM(Integrated Audio Module)																	
S Series(SEDANS)	S60	2011	CCM(Climate control module)		V	V														
S Series(SEDANS)	S60	2011	AUD(AUdio Module)																	
S Series(SEDANS)	S60	2011	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2011	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2011	KVM(Keyless Vehicle Module)				V	V	V	V	V									
S Series(SEDANS)	S60	2010	System Search																	
S Series(SEDANS)	S60	2010	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2010	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S60	2010	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S60	2010	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S60	2010	BCM(Brake Control Module)																	
S Series(SEDANS)	S60	2010	PBM(Park Brake Module)																	
S Series(SEDANS)	S60	2010	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2010	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S60	2010	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S60	2010	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2010	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S60	2010	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2010	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S60	2010	PDM(Passenger door module)																	
S Series(SEDANS)	S60	2010	IAM(Integrated Audio Module)																	
S Series(SEDANS)	S60	2010	CCM(Climate control module)		V	V														
S Series(SEDANS)	S60	2010	AUD(AUdio Module)																	
S Series(SEDANS)	S60	2010	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2010	PSM(Power Seat Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S60	2010	KVM(Keyless Vehicle Module)				V	V	V	V	V									
S Series(SEDANS)	S60	2009	System Search																	
S Series(SEDANS)	S60	2009	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2009	TCM(Transmission Control Module)																	
S Series(SEDANS)	S60	2009	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S60	2009	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2009	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2009	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2009	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2009	PDM(Passenger Door Module)																	
S Series(SEDANS)	S60	2009	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2009	CCM(Climate Control Module)																	
S Series(SEDANS)	S60	2009	SAS(Steering Wheel Angle Sensor Module)																	
S Series(SEDANS)	S60	2009	UEM(Up Electrical Module)																	
S Series(SEDANS)	S60	2009	REM(Rear Electrical Module)																	
S Series(SEDANS)	S60	2009	AUM(Audio Module)																	
S Series(SEDANS)	S60	2008	System Search																	
S Series(SEDANS)	S60	2008	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2008	TCM(Transmission Control Module)																	
S Series(SEDANS)	S60	2008	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S60	2008	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2008	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2008	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2008	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2008	PDM(Passenger Door Module)																	
S Series(SEDANS)	S60	2008	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2008	CCM(Climate Control Module)																	
S Series(SEDANS)	S60	2008	SAS(Steering Wheel Angle Sensor Module)																	
S Series(SEDANS)	S60	2008	UEM(Up Electrical Module)																	
S Series(SEDANS)	S60	2008	REM(Rear Electrical Module)																	
S Series(SEDANS)	S60	2008	AUM(Audio Module)																	
S Series(SEDANS)	S60	2007	System Search																	
S Series(SEDANS)	S60	2007	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2007	TCM(Transmission Control Module)																	
S Series(SEDANS)	S60	2007	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S60	2007	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2007	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2007	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2007	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2007	PDM(Passenger Door Module)																	
S Series(SEDANS)	S60	2007	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2007	CCM(Climate Control Module)																	
S Series(SEDANS)	S60	2007	SAS(Steering Wheel Angle Sensor Module)																	
S Series(SEDANS)	S60	2007	UEM(Up Electrical Module)																	
S Series(SEDANS)	S60	2007	REM(Rear Electrical Module)																	
S Series(SEDANS)	S60	2007	AUM(Audio Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S60	2006	System Search																	
S Series(SEDANS)	S60	2006	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2006	TCM(Transmission Control Module)																	
S Series(SEDANS)	S60	2006	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S60	2006	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2006	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2006	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2006	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2006	PDM(Passenger Door Module)																	
S Series(SEDANS)	S60	2006	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2006	CCM(Climate Control Module)																	
S Series(SEDANS)	S60	2006	SAS(Steering Wheel Angle Sensor Module)																	
S Series(SEDANS)	S60	2006	UEM(Up Electrical Module)																	
S Series(SEDANS)	S60	2006	REM(Rear Electrical Module)																	
S Series(SEDANS)	S60	2006	AUM(Audio Module)																	
S Series(SEDANS)	S60	2005	System Search																	
S Series(SEDANS)	S60	2005	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2005	TCM(Transmission Control Module)																	
S Series(SEDANS)	S60	2005	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S60	2005	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2005	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2005	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2005	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2005	PDM(Passenger Door Module)																	
S Series(SEDANS)	S60	2005	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2005	CCM(Climate Control Module)																	
S Series(SEDANS)	S60	2005	SAS(Steering Wheel Angle Sensor Module)																	
S Series(SEDANS)	S60	2005	UEM(Up Electrical Module)																	
S Series(SEDANS)	S60	2005	REM(Rear Electrical Module)																	
S Series(SEDANS)	S60	2005	AUM(Audio Module)																	
S Series(SEDANS)	S60	2004	System Search																	
S Series(SEDANS)	S60	2004	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2004	TCM(Transmission Control Module)																	
S Series(SEDANS)	S60	2004	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S60	2004	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2004	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2004	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2004	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2004	PDM(Passenger Door Module)																	
S Series(SEDANS)	S60	2004	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2004	CCM(Climate Control Module)																	
S Series(SEDANS)	S60	2004	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S60	2004	UEM(Up Electrical Module)																	
S Series(SEDANS)	S60	2004	REM(Rear Electrical Module)																	
S Series(SEDANS)	S60	2004	AUM(Audio Module)																	
S Series(SEDANS)	S60	2003	System Search																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S60	2003	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2003	TCM(Transmission Control Module)																	
S Series(SEDANS)	S60	2003	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S60	2003	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2003	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2003	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2003	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2003	PDM(Passenger Door Module)																	
S Series(SEDANS)	S60	2003	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2003	CCM(Climate Control Module)																	
S Series(SEDANS)	S60	2003	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S60	2003	UEM(Up Electrical Module)																	
S Series(SEDANS)	S60	2003	REM(Rear Electrical Module)																	
S Series(SEDANS)	S60	2003	AUM(Audio Module)																	
S Series(SEDANS)	S60	2002	System Search																	
S Series(SEDANS)	S60	2002	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2002	TCM(Transmission Control Module)																	
S Series(SEDANS)	S60	2002	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S60	2002	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2002	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2002	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2002	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2002	PDM(Passenger Door Module)																	
S Series(SEDANS)	S60	2002	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2002	CCM(Climate Control Module)																	
S Series(SEDANS)	S60	2002	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S60	2002	UEM(Up Electrical Module)																	
S Series(SEDANS)	S60	2002	REM(Rear Electrical Module)																	
S Series(SEDANS)	S60	2002	AUM(Audio Module)																	
S Series(SEDANS)	S60	2001	System Search																	
S Series(SEDANS)	S60	2001	ECM(Engine Control Module)																	
S Series(SEDANS)	S60	2001	TCM(Transmission Control Module)																	
S Series(SEDANS)	S60	2001	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S60	2001	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S60	2001	CEM(Central Electrical Module)																	
S Series(SEDANS)	S60	2001	DIM(Driver Information Module)																	
S Series(SEDANS)	S60	2001	DDM(Driver Door Module)																	
S Series(SEDANS)	S60	2001	PDM(Passenger Door Module)																	
S Series(SEDANS)	S60	2001	PSM(Power Seat Module)																	
S Series(SEDANS)	S60	2001	CCM(Climate Control Module)																	
S Series(SEDANS)	S60	2001	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S60	2001	UEM(Up Electrical Module)																	
S Series(SEDANS)	S60	2001	REM(Rear Electrical Module)																	
S Series(SEDANS)	S60	2001	AUM(Audio Module)																	
S Series(SEDANS)	S70	2000	System Search																	
S Series(SEDANS)	S70	2000	ECM(Engine Control Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S70	2000	TCM(Transmission Control Module)																	
S Series(SEDANS)	S70	2000	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S70	1999	System Search																	
S Series(SEDANS)	S70	1999	ECM(Engine Control Module)																	
S Series(SEDANS)	S70	1999	TCM(Transmission Control Module)																	
S Series(SEDANS)	S70	1999	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S80	2014	System Search																	
S Series(SEDANS)	S80	2014	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2014	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S80	2014	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S80	2014	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S80	2014	BCM(Brake Control Module)																	
S Series(SEDANS)	S80	2014	PBM(Park Brake Module)																	
S Series(SEDANS)	S80	2014	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2014	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S80	2014	FSM(Forward Sensing Module)																	
S Series(SEDANS)	S80	2014	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S80	2014	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2014	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S80	2014	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2014	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S80	2014	PDM(Passenger door module)																	
S Series(SEDANS)	S80	2014	CCM(Climate control module)																	
S Series(SEDANS)	S80	2014	AUD(AUdio Module)																	
S Series(SEDANS)	S80	2014	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2014	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2014	DEM(Differential Electronic Module)																	
S Series(SEDANS)	S80	2014	KVM(Keyless Vehicle Module)				V	V	V	V	V									
S Series(SEDANS)	S80	2014	POT(Power operated tailgate module)																	
S Series(SEDANS)	S80	2014	SODR(Side Obstacle Detection control module Right)																	
S Series(SEDANS)	S80	2014	SODL(Side Obstacle Detection control module Left)																	
S Series(SEDANS)	S80	2014	RDAR(Remote Digital Audio Receiver)																	
S Series(SEDANS)	S80	2014	HCM(Headlamp control module)																	
S Series(SEDANS)	S80	2014	BPM(Bluetooth phone module)																	
S Series(SEDANS)	S80	2013	System Search																	
S Series(SEDANS)	S80	2013	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2013	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S80	2013	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S80	2013	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S80	2013	BCM(Brake Control Module)																	
S Series(SEDANS)	S80	2013	PBM(Park Brake Module)																	
S Series(SEDANS)	S80	2013	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2013	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S80	2013	FSM(Forward Sensing Module)																	
S Series(SEDANS)	S80	2013	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S80	2013	DIM(Driver Information Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S80	2013	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S80	2013	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2013	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S80	2013	PDM(Passenger door module)																	
S Series(SEDANS)	S80	2013	CCM(Climate control module)																	
S Series(SEDANS)	S80	2013	AUD(AUdio Module)																	
S Series(SEDANS)	S80	2013	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2013	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2013	DEM(Differential Electronic Module)																	
S Series(SEDANS)	S80	2013	KVM(Keyless Vehicle Module)			V	V	V	V	V										
S Series(SEDANS)	S80	2013	POT(Power operated tailgate module)																	
S Series(SEDANS)	S80	2013	SODR(Side Obstacle Detection control module Right)																	
S Series(SEDANS)	S80	2013	SODL(Side Obstacle Detection control module Left)																	
S Series(SEDANS)	S80	2013	RDAR(Remote Digital Audio Receiver)																	
S Series(SEDANS)	S80	2013	HCM(Headlamp control module)																	
S Series(SEDANS)	S80	2013	BPM(Bluetooth phone module)																	
S Series(SEDANS)	S80	2012	System Search																	
S Series(SEDANS)	S80	2012	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2012	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S80	2012	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S80	2012	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S80	2012	BCM(Brake Control Module)																	
S Series(SEDANS)	S80	2012	PBM(Park Brake Module)																	
S Series(SEDANS)	S80	2012	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2012	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S80	2012	FSM(Forward Sensing Module)																	
S Series(SEDANS)	S80	2012	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S80	2012	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2012	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S80	2012	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2012	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S80	2012	PDM(Passenger door module)																	
S Series(SEDANS)	S80	2012	CCM(Climate control module)																	
S Series(SEDANS)	S80	2012	AUD(AUdio Module)																	
S Series(SEDANS)	S80	2012	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2012	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2012	DEM(Differential Electronic Module)																	
S Series(SEDANS)	S80	2012	KVM(Keyless Vehicle Module)			V	V	V	V	V										
S Series(SEDANS)	S80	2012	POT(Power operated tailgate module)																	
S Series(SEDANS)	S80	2012	SODR(Side Obstacle Detection control module Right)																	
S Series(SEDANS)	S80	2012	SODL(Side Obstacle Detection control module Left)																	
S Series(SEDANS)	S80	2012	RDAR(Remote Digital Audio Receiver)																	
S Series(SEDANS)	S80	2012	HCM(Headlamp control module)																	
S Series(SEDANS)	S80	2012	BPM(Bluetooth phone module)																	
S Series(SEDANS)	S80	2011	System Search																	
S Series(SEDANS)	S80	2011	ECM(Engine Control Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S80	2011	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S80	2011	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S80	2011	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S80	2011	BCM(Brake Control Module)																	
S Series(SEDANS)	S80	2011	PBM(Park Brake Module)																	
S Series(SEDANS)	S80	2011	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2011	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S80	2011	FSM(Forward Sensing Module)																	
S Series(SEDANS)	S80	2011	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S80	2011	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2011	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S80	2011	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2011	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S80	2011	PDM(Passenger door module)																	
S Series(SEDANS)	S80	2011	CCM(Climate control module)																	
S Series(SEDANS)	S80	2011	AUD(AUdio Module)																	
S Series(SEDANS)	S80	2011	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2011	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2011	DEM(Differential Electronic Module)																	
S Series(SEDANS)	S80	2011	KVM(Keyless Vehicle Module)				V	V	V	V	V									
S Series(SEDANS)	S80	2011	POT(Power operated tailgate module)																	
S Series(SEDANS)	S80	2011	SODR(Side Obstacle Detection control module Right)																	
S Series(SEDANS)	S80	2011	SODL(Side Obstacle Detection control module Left)																	
S Series(SEDANS)	S80	2011	RDAR(Remote Digital Audio Receiver)																	
S Series(SEDANS)	S80	2011	HCM(Headlamp control module)																	
S Series(SEDANS)	S80	2011	BPM(Bluetooth phone module)																	
S Series(SEDANS)	S80	2010	System Search																	
S Series(SEDANS)	S80	2010	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2010	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S80	2010	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S80	2010	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S80	2010	BCM(Brake Control Module)																	
S Series(SEDANS)	S80	2010	PBM(Park Brake Module)																	
S Series(SEDANS)	S80	2010	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2010	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S80	2010	FSM(Forward Sensing Module)																	
S Series(SEDANS)	S80	2010	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S80	2010	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2010	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S80	2010	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2010	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S80	2010	PDM(Passenger door module)																	
S Series(SEDANS)	S80	2010	CCM(Climate control module)																	
S Series(SEDANS)	S80	2010	AUD(AUdio Module)																	
S Series(SEDANS)	S80	2010	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2010	PSM(Power Seat Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S80	2010	DEM(Differential Electronic Module)																	
S Series(SEDANS)	S80	2010	KVM(Keyless Vehicle Module)				V	V	V	V	V									
S Series(SEDANS)	S80	2010	POT(Power operated tailgate module)																	
S Series(SEDANS)	S80	2010	SODR(Side Obstacle Detection control module Right)																	
S Series(SEDANS)	S80	2010	SODL(Side Obstacle Detection control module Left)																	
S Series(SEDANS)	S80	2010	RDAR(Remote Digital Audio Receiver)																	
S Series(SEDANS)	S80	2010	HCM(Headlamp control module)																	
S Series(SEDANS)	S80	2010	BPM(Bluetooth phone module)																	
S Series(SEDANS)	S80	2009	System Search																	
S Series(SEDANS)	S80	2009	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2009	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S80	2009	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S80	2009	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S80	2009	BCM(Brake Control Module)																	
S Series(SEDANS)	S80	2009	PBM(Park Brake Module)																	
S Series(SEDANS)	S80	2009	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2009	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S80	2009	FSM(Forward Sensing Module)																	
S Series(SEDANS)	S80	2009	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S80	2009	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2009	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S80	2009	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2009	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S80	2009	PDM(Passenger door module)																	
S Series(SEDANS)	S80	2009	CCM(Climate control module)																	
S Series(SEDANS)	S80	2009	AUD(AUdio Module)																	
S Series(SEDANS)	S80	2009	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2009	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2009	DEM(Differential Electronic Module)																	
S Series(SEDANS)	S80	2009	KVM(Keyless Vehicle Module)				V	V	V	V	V									
S Series(SEDANS)	S80	2009	POT(Power operated tailgate module)																	
S Series(SEDANS)	S80	2009	SODR(Side Obstacle Detection control module Right)																	
S Series(SEDANS)	S80	2009	SODL(Side Obstacle Detection control module Left)																	
S Series(SEDANS)	S80	2009	RDAR(Remote Digital Audio Receiver)																	
S Series(SEDANS)	S80	2009	HCM(Headlamp control module)																	
S Series(SEDANS)	S80	2009	BPM(Bluetooth phone module)																	
S Series(SEDANS)	S80	2008	System Search																	
S Series(SEDANS)	S80	2008	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2008	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S80	2008	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S80	2008	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S80	2008	BCM(Brake Control Module)																	
S Series(SEDANS)	S80	2008	PBM(Park Brake Module)																	
S Series(SEDANS)	S80	2008	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2008	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S80	2008	FSM(Forward Sensing Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S80	2008	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S80	2008	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2008	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S80	2008	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2008	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S80	2008	PDM(Passenger door module)																	
S Series(SEDANS)	S80	2008	CCM(Climate control module)																	
S Series(SEDANS)	S80	2008	AUD(AUdio Module)																	
S Series(SEDANS)	S80	2008	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2008	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2008	DEM(Differential Electronic Module)																	
S Series(SEDANS)	S80	2008	KVM(Keyless Vehicle Module)				V	V	V	V	V									
S Series(SEDANS)	S80	2008	POT(Power operated tailgate module)																	
S Series(SEDANS)	S80	2008	SODR(Side Obstacle Detection control module Right)																	
S Series(SEDANS)	S80	2008	SODL(Side Obstacle Detection control module Left)																	
S Series(SEDANS)	S80	2008	RDAR(Remote Digital Audio Receiver)																	
S Series(SEDANS)	S80	2008	HCM(Headlamp control module)																	
S Series(SEDANS)	S80	2008	BPM(Bluetooth phone module)																	
S Series(SEDANS)	S80	2007	System Search																	
S Series(SEDANS)	S80	2007	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2007	TCM(Transmission Control Module)	TF-80SC																
S Series(SEDANS)	S80	2007	TCM(Transmission Control Module)	TG-81SC																
S Series(SEDANS)	S80	2007	SAS(Steering Angle Sensor module)																	
S Series(SEDANS)	S80	2007	BCM(Brake Control Module)																	
S Series(SEDANS)	S80	2007	PBM(Park Brake Module)																	
S Series(SEDANS)	S80	2007	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2007	PSCM(Power Steering Control Module)																	
S Series(SEDANS)	S80	2007	FSM(Forward Sensing Module)																	
S Series(SEDANS)	S80	2007	CVM(Closing Velocity Module)																	
S Series(SEDANS)	S80	2007	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2007	PAM(Parking Assistance Module)																	
S Series(SEDANS)	S80	2007	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2007	ICM(Infotainment Control Module)																	
S Series(SEDANS)	S80	2007	PDM(Passenger door module)																	
S Series(SEDANS)	S80	2007	CCM(Climate control module)																	
S Series(SEDANS)	S80	2007	AUD(AUdio Module)																	
S Series(SEDANS)	S80	2007	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2007	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2007	DEM(Differential Electronic Module)																	
S Series(SEDANS)	S80	2007	KVM(Keyless Vehicle Module)				V	V	V	V	V									
S Series(SEDANS)	S80	2007	POT(Power operated tailgate module)																	
S Series(SEDANS)	S80	2007	SODR(Side Obstacle Detection control module Right)																	
S Series(SEDANS)	S80	2007	SODL(Side Obstacle Detection control module Left)																	
S Series(SEDANS)	S80	2007	RDAR(Remote Digital Audio Receiver)																	
S Series(SEDANS)	S80	2007	HCM(Headlamp control module)																	
S Series(SEDANS)	S80	2007	BPM(Bluetooth phone module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S80	2006	System Search																	
S Series(SEDANS)	S80	2006	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2006	TCM(Transmission Control Module)																	
S Series(SEDANS)	S80	2006	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S80	2006	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2006	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2006	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2006	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2006	PDM(Passenger Door Module)																	
S Series(SEDANS)	S80	2006	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2006	CCM(Climate Control Module)																	
S Series(SEDANS)	S80	2006	SAS(Steering Wheel Angle Sensor Module)																	
S Series(SEDANS)	S80	2006	UEM(Up Electrical Module)																	
S Series(SEDANS)	S80	2006	REM(Rear Electrical Module)																	
S Series(SEDANS)	S80	2006	AUM(Audio Module)																	
S Series(SEDANS)	S80	2005	System Search																	
S Series(SEDANS)	S80	2005	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2005	TCM(Transmission Control Module)																	
S Series(SEDANS)	S80	2005	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S80	2005	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2005	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2005	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2005	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2005	PDM(Passenger Door Module)																	
S Series(SEDANS)	S80	2005	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2005	CCM(Climate Control Module)																	
S Series(SEDANS)	S80	2005	SAS(Steering Wheel Angle Sensor Module)																	
S Series(SEDANS)	S80	2005	UEM(Up Electrical Module)																	
S Series(SEDANS)	S80	2005	REM(Rear Electrical Module)																	
S Series(SEDANS)	S80	2005	AUM(Audio Module)																	
S Series(SEDANS)	S80	2004	System Search																	
S Series(SEDANS)	S80	2004	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2004	TCM(Transmission Control Module)																	
S Series(SEDANS)	S80	2004	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S80	2004	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2004	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2004	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2004	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2004	PDM(Passenger Door Module)																	
S Series(SEDANS)	S80	2004	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2004	CCM(Climate Control Module)																	
S Series(SEDANS)	S80	2004	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S80	2004	UEM(Up Electrical Module)																	
S Series(SEDANS)	S80	2004	REM(Rear Electrical Module)																	
S Series(SEDANS)	S80	2004	AUM(Audio Module)																	
S Series(SEDANS)	S80	2003	System Search																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S80	2003	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2003	TCM(Transmission Control Module)																	
S Series(SEDANS)	S80	2003	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S80	2003	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2003	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2003	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2003	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2003	PDM(Passenger Door Module)																	
S Series(SEDANS)	S80	2003	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2003	CCM(Climate Control Module)																	
S Series(SEDANS)	S80	2003	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S80	2003	UEM(Up Electrical Module)																	
S Series(SEDANS)	S80	2003	REM(Rear Electrical Module)																	
S Series(SEDANS)	S80	2003	AUM(Audio Module)																	
S Series(SEDANS)	S80	2002	System Search																	
S Series(SEDANS)	S80	2002	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2002	TCM(Transmission Control Module)																	
S Series(SEDANS)	S80	2002	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S80	2002	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2002	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2002	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2002	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2002	PDM(Passenger Door Module)																	
S Series(SEDANS)	S80	2002	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2002	CCM(Climate Control Module)																	
S Series(SEDANS)	S80	2002	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S80	2002	UEM(Up Electrical Module)																	
S Series(SEDANS)	S80	2002	REM(Rear Electrical Module)																	
S Series(SEDANS)	S80	2002	AUM(Audio Module)																	
S Series(SEDANS)	S80	2001	System Search																	
S Series(SEDANS)	S80	2001	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	2001	TCM(Transmission Control Module)																	
S Series(SEDANS)	S80	2001	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S80	2001	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2001	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2001	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2001	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2001	PDM(Passenger Door Module)																	
S Series(SEDANS)	S80	2001	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2001	CCM(Climate Control Module)																	
S Series(SEDANS)	S80	2001	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S80	2001	UEM(Up Electrical Module)																	
S Series(SEDANS)	S80	2001	REM(Rear Electrical Module)																	
S Series(SEDANS)	S80	2001	AUM(Audio Module)																	
S Series(SEDANS)	S80	2000	System Search																	
S Series(SEDANS)	S80	2000	ECM(Engine Control Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
S Series(SEDANS)	S80	2000	TCM(Transmission Control Module)																	
S Series(SEDANS)	S80	2000	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S80	2000	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	2000	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	2000	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	2000	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	2000	PDM(Passenger Door Module)																	
S Series(SEDANS)	S80	2000	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	2000	CCM(Climate Control Module)																	
S Series(SEDANS)	S80	2000	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S80	2000	UEM(Up Electrical Module)																	
S Series(SEDANS)	S80	2000	REM(Rear Electrical Module)																	
S Series(SEDANS)	S80	2000	AUM(Audio Module)																	
S Series(SEDANS)	S80	1999	System Search																	
S Series(SEDANS)	S80	1999	ECM(Engine Control Module)																	
S Series(SEDANS)	S80	1999	TCM(Transmission Control Module)																	
S Series(SEDANS)	S80	1999	ABS(Anti-Lock Brake System)																	
S Series(SEDANS)	S80	1999	SRS(Supplemental Restraint System)																	
S Series(SEDANS)	S80	1999	CEM(Central Electrical Module)																	
S Series(SEDANS)	S80	1999	DIM(Driver Information Module)																	
S Series(SEDANS)	S80	1999	DDM(Driver Door Module)																	
S Series(SEDANS)	S80	1999	PDM(Passenger Door Module)																	
S Series(SEDANS)	S80	1999	PSM(Power Seat Module)																	
S Series(SEDANS)	S80	1999	CCM(Climate Control Module)																	
S Series(SEDANS)	S80	1999	SWM(Steering Wheel Module)																	
S Series(SEDANS)	S80	1999	UEM(Up Electrical Module)																	
S Series(SEDANS)	S80	1999	REM(Rear Electrical Module)																	
S Series(SEDANS)	S80	1999	AUM(Audio Module)																	
V Series(WAGONS)	Maintenance	BCM(Brake control module) Service function																		
V Series(WAGONS)	Maintenance	PBM(Parking brake module) Service function																		
V Series(WAGONS)	Maintenance	Service Reminder Reset																		
V Series(WAGONS)	Maintenance	Technical Information																		
V Series(WAGONS)	V40	2014	System Search																	
V Series(WAGONS)	V40	2014	ECM(Engine Control Module)																	
V Series(WAGONS)	V40	2014	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V40	2014	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V40	2014	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V40	2014	BCM(Brake Control Module)																	
V Series(WAGONS)	V40	2014	SRS(Supplemental Restraint System)											V	V					
V Series(WAGONS)	V40	2014	PSCM(Power Steering Control Module)																	
V Series(WAGONS)	V40	2014	CVM(Closing Velocity Module)																	
V Series(WAGONS)	V40	2014	DIM(Driver Information Module)																	
V Series(WAGONS)	V40	2014	FSM(Forward Sensing Module)																	
V Series(WAGONS)	V40	2014	PAM(Parking Assistance Module)																	
V Series(WAGONS)	V40	2014	CEM(Central Electrical Module)													V	V	V	V	V
V Series(WAGONS)	V40	2014	ICM(Infotainment Control Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
V Series(WAGONS)	V40	2014	PDM(Passenger door module)																	
V Series(WAGONS)	V40	2014	IAM(Integrated Audio Module)																	
V Series(WAGONS)	V40	2014	CCM(Climate control module)		V	V														
V Series(WAGONS)	V40	2014	AUD(AUdio Module)																	
V Series(WAGONS)	V40	2014	DDM(Driver Door Module)																	
V Series(WAGONS)	V40	2014	PPM(Pedestrian Protection Module)																	
V Series(WAGONS)	V40	2014	SODR(Side Obstacle Detection control module Right)																	
V Series(WAGONS)	V40	2014	SODL(Side Obstacle Detection control module Left)																	
V Series(WAGONS)	V40	2013	System Search																	
V Series(WAGONS)	V40	2013	ECM(Engine Control Module)																	
V Series(WAGONS)	V40	2013	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V40	2013	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V40	2013	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V40	2013	BCM(Brake Control Module)																	
V Series(WAGONS)	V40	2013	SRS(Supplemental Restraint System)											V	V					
V Series(WAGONS)	V40	2013	PSCM(Power Steering Control Module)																	
V Series(WAGONS)	V40	2013	CVM(Closing Velocity Module)																	
V Series(WAGONS)	V40	2013	DIM(Driver Information Module)																	
V Series(WAGONS)	V40	2013	PAM(Parking Assistance Module)																	
V Series(WAGONS)	V40	2013	FSM(Forward Sensing Module)																	
V Series(WAGONS)	V40	2013	CEM(Central Electrical Module)													V	V	V	V	V
V Series(WAGONS)	V40	2013	ICM(Infotainment Control Module)																	
V Series(WAGONS)	V40	2013	PDM(Passenger door module)																	
V Series(WAGONS)	V40	2013	IAM(Integrated Audio Module)																	
V Series(WAGONS)	V40	2013	CCM(Climate control module)		V	V														
V Series(WAGONS)	V40	2013	AUD(AUdio Module)																	
V Series(WAGONS)	V40	2013	DDM(Driver Door Module)																	
V Series(WAGONS)	V40	2013	PPM(Pedestrian Protection Module)																	
V Series(WAGONS)	V40	2013	SODR(Side Obstacle Detection control module Right)																	
V Series(WAGONS)	V40	2013	SODL(Side Obstacle Detection control module Left)																	
V Series(WAGONS)	V40	2012	System Search																	
V Series(WAGONS)	V40	2012	ECM(Engine Control Module)																	
V Series(WAGONS)	V40	2012	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V40	2012	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V40	2012	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V40	2012	BCM(Brake Control Module)																	
V Series(WAGONS)	V40	2012	SRS(Supplemental Restraint System)											V	V					
V Series(WAGONS)	V40	2012	PSCM(Power Steering Control Module)																	
V Series(WAGONS)	V40	2012	CVM(Closing Velocity Module)																	
V Series(WAGONS)	V40	2012	DIM(Driver Information Module)																	
V Series(WAGONS)	V40	2012	PAM(Parking Assistance Module)																	
V Series(WAGONS)	V40	2012	FSM(Forward Sensing Module)																	
V Series(WAGONS)	V40	2012	CEM(Central Electrical Module)													V	V	V	V	V
V Series(WAGONS)	V40	2012	ICM(Infotainment Control Module)																	
V Series(WAGONS)	V40	2012	PDM(Passenger door module)																	
V Series(WAGONS)	V40	2012	IAM(Integrated Audio Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
V Series(WAGONS)	V40	2012	CCM(Climate control module)		V	V														
V Series(WAGONS)	V40	2012	AUD(AUdio Module)																	
V Series(WAGONS)	V40	2012	DDM(Driver Door Module)																	
V Series(WAGONS)	V40	2012	PPM(Pedestrian Protection Module)																	
V Series(WAGONS)	V40	2012	SODR(Side Obstacle Detection control module Right)																	
V Series(WAGONS)	V40	2012	SODL(Side Obstacle Detection control module Left)																	
V Series(WAGONS)	V50	2012	System Search																	
V Series(WAGONS)	V50	2012	ECM(Engine Control Module)																	
V Series(WAGONS)	V50	2012	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V50	2012	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V50	2012	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V50	2012	BCM(Brake Control Module)																	
V Series(WAGONS)	V50	2012	SRS(Supplemental Restraint System)																	
V Series(WAGONS)	V50	2012	DIM(Driver Information Module)																	
V Series(WAGONS)	V50	2012	PDM(Passenger door module)																	
V Series(WAGONS)	V50	2012	CCM(Climate control module)																	
V Series(WAGONS)	V50	2012	DDM(Driver Door Module)																	
V Series(WAGONS)	V50	2012	EPS(Electrical power steering module)																	
V Series(WAGONS)	V50	2012	HCM(Headlamp control module)																	
V Series(WAGONS)	V50	2011	System Search																	
V Series(WAGONS)	V50	2011	ECM(Engine Control Module)																	
V Series(WAGONS)	V50	2011	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V50	2011	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V50	2011	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V50	2011	BCM(Brake Control Module)																	
V Series(WAGONS)	V50	2011	SRS(Supplemental Restraint System)																	
V Series(WAGONS)	V50	2011	DIM(Driver Information Module)																	
V Series(WAGONS)	V50	2011	PDM(Passenger door module)																	
V Series(WAGONS)	V50	2011	CCM(Climate control module)																	
V Series(WAGONS)	V50	2011	DDM(Driver Door Module)																	
V Series(WAGONS)	V50	2011	EPS(Electrical power steering module)																	
V Series(WAGONS)	V50	2011	HCM(Headlamp control module)																	
V Series(WAGONS)	V50	2010	System Search																	
V Series(WAGONS)	V50	2010	ECM(Engine Control Module)																	
V Series(WAGONS)	V50	2010	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V50	2010	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V50	2010	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V50	2010	BCM(Brake Control Module)																	
V Series(WAGONS)	V50	2010	SRS(Supplemental Restraint System)																	
V Series(WAGONS)	V50	2010	DIM(Driver Information Module)																	
V Series(WAGONS)	V50	2010	PDM(Passenger door module)																	
V Series(WAGONS)	V50	2010	CCM(Climate control module)																	
V Series(WAGONS)	V50	2010	DDM(Driver Door Module)																	
V Series(WAGONS)	V50	2010	EPS(Electrical power steering module)																	
V Series(WAGONS)	V50	2010	HCM(Headlamp control module)																	
V Series(WAGONS)	V50	2010	ABS(Anti-Lock Brake System)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
V Series(WAGONS)	V50	2010	CEM(Central Electrical Module)																	
V Series(WAGONS)	V50	2010	PSM(Power Seat Module)																	
V Series(WAGONS)	V50	2010	SWM(Steering Wheel Module)																	
V Series(WAGONS)	V50	2009	System Search																	
V Series(WAGONS)	V50	2009	ECM(Engine Control Module)																	
V Series(WAGONS)	V50	2009	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V50	2009	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V50	2009	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V50	2009	BCM(Brake Control Module)																	
V Series(WAGONS)	V50	2009	SRS(Supplemental Restraint System)																	
V Series(WAGONS)	V50	2009	DIM(Driver Information Module)																	
V Series(WAGONS)	V50	2009	PDM(Passenger door module)																	
V Series(WAGONS)	V50	2009	CCM(Climate control module)																	
V Series(WAGONS)	V50	2009	DDM(Driver Door Module)																	
V Series(WAGONS)	V50	2009	EPS(Electrical power steering module)																	
V Series(WAGONS)	V50	2009	HCM(Headlamp control module)																	
V Series(WAGONS)	V50	2009	ABS(Anti-Lock Brake System)																	
V Series(WAGONS)	V50	2009	CEM(Central Electrical Module)																	
V Series(WAGONS)	V50	2009	PSM(Power Seat Module)																	
V Series(WAGONS)	V50	2009	SWM(Steering Wheel Module)																	
V Series(WAGONS)	V50	2008	System Search																	
V Series(WAGONS)	V50	2008	ECM(Engine Control Module)																	
V Series(WAGONS)	V50	2008	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V50	2008	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V50	2008	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V50	2008	BCM(Brake Control Module)																	
V Series(WAGONS)	V50	2008	SRS(Supplemental Restraint System)																	
V Series(WAGONS)	V50	2008	DIM(Driver Information Module)																	
V Series(WAGONS)	V50	2008	PDM(Passenger door module)																	
V Series(WAGONS)	V50	2008	CCM(Climate control module)																	
V Series(WAGONS)	V50	2008	DDM(Driver Door Module)																	
V Series(WAGONS)	V50	2008	EPS(Electrical power steering module)																	
V Series(WAGONS)	V50	2008	HCM(Headlamp control module)																	
V Series(WAGONS)	V50	2008	ABS(Anti-Lock Brake System)																	
V Series(WAGONS)	V50	2008	CEM(Central Electrical Module)																	
V Series(WAGONS)	V50	2008	PSM(Power Seat Module)																	
V Series(WAGONS)	V50	2008	SWM(Steering Wheel Module)																	
V Series(WAGONS)	V50	2007	System Search																	
V Series(WAGONS)	V50	2007	ECM(Engine Control Module)																	
V Series(WAGONS)	V50	2007	TCM(Transmission Control Module)																	
V Series(WAGONS)	V50	2007	ABS(Anti-Lock Brake System)																	
V Series(WAGONS)	V50	2007	SRS(Supplemental Restraint System)																	
V Series(WAGONS)	V50	2007	CEM(Central Electrical Module)																	
V Series(WAGONS)	V50	2007	DIM(Driver Information Module)																	
V Series(WAGONS)	V50	2007	DDM(Driver Door Module)																	
V Series(WAGONS)	V50	2007	PDM(Passenger Door Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
V Series(WAGONS)	V50	2007	PSM(Power Seat Module)																	
V Series(WAGONS)	V50	2007	CCM(Climate Control Module)																	
V Series(WAGONS)	V50	2007	SWM(Steering Wheel Module)																	
V Series(WAGONS)	V50	2006	System Search																	
V Series(WAGONS)	V50	2006	ECM(Engine Control Module)																	
V Series(WAGONS)	V50	2006	TCM(Transmission Control Module)																	
V Series(WAGONS)	V50	2006	ABS(Anti-Lock Brake System)																	
V Series(WAGONS)	V50	2006	SRS(Supplemental Restraint System)																	
V Series(WAGONS)	V50	2006	CEM(Central Electrical Module)																	
V Series(WAGONS)	V50	2006	DIM(Driver Information Module)																	
V Series(WAGONS)	V50	2006	DDM(Driver Door Module)																	
V Series(WAGONS)	V50	2006	PDM(Passenger Door Module)																	
V Series(WAGONS)	V50	2006	PSM(Power Seat Module)																	
V Series(WAGONS)	V50	2006	CCM(Climate Control Module)																	
V Series(WAGONS)	V50	2006	SWM(Steering Wheel Module)																	
V Series(WAGONS)	V50	2005	System Search																	
V Series(WAGONS)	V50	2005	ECM(Engine Control Module)																	
V Series(WAGONS)	V50	2005	TCM(Transmission Control Module)																	
V Series(WAGONS)	V50	2005	ABS(Anti-Lock Brake System)																	
V Series(WAGONS)	V50	2005	SRS(Supplemental Restraint System)																	
V Series(WAGONS)	V50	2005	CEM(Central Electrical Module)																	
V Series(WAGONS)	V50	2005	DIM(Driver Information Module)																	
V Series(WAGONS)	V50	2005	DDM(Driver Door Module)																	
V Series(WAGONS)	V50	2005	PDM(Passenger Door Module)																	
V Series(WAGONS)	V50	2005	PSM(Power Seat Module)																	
V Series(WAGONS)	V50	2005	CCM(Climate Control Module)																	
V Series(WAGONS)	V50	2005	SWM(Steering Wheel Module)																	
V Series(WAGONS)	V50	2004	System Search																	
V Series(WAGONS)	V50	2004	ECM(Engine Control Module)																	
V Series(WAGONS)	V50	2004	TCM(Transmission Control Module)																	
V Series(WAGONS)	V50	2004	ABS(Anti-Lock Brake System)																	
V Series(WAGONS)	V50	2004	SRS(Supplemental Restraint System)																	
V Series(WAGONS)	V50	2004	CEM(Central Electrical Module)																	
V Series(WAGONS)	V50	2004	DIM(Driver Information Module)																	
V Series(WAGONS)	V50	2004	DDM(Driver Door Module)																	
V Series(WAGONS)	V50	2004	PDM(Passenger Door Module)																	
V Series(WAGONS)	V50	2004	PSM(Power Seat Module)																	
V Series(WAGONS)	V50	2004	CCM(Climate Control Module)																	
V Series(WAGONS)	V50	2004	SWM(Steering Wheel Module)																	
V Series(WAGONS)	V60	2014	System Search																	
V Series(WAGONS)	V60	2014	ECM(Engine Control Module)																	
V Series(WAGONS)	V60	2014	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V60	2014	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V60	2014	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V60	2014	BCM(Brake Control Module)																	
V Series(WAGONS)	V60	2014	PBM(Park Brake Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
V Series(WAGONS)	V60	2014	SRS(Supplemental Restraint System)											V	V					
V Series(WAGONS)	V60	2014	PSCM(Power Steering Control Module)																	
V Series(WAGONS)	V60	2014	FSM(Forward Sensing Module)																	
V Series(WAGONS)	V60	2014	CVM(Closing Velocity Module)																	
V Series(WAGONS)	V60	2014	DIM(Driver Information Module)																	
V Series(WAGONS)	V60	2014	SUM(SUspension Module)																	
V Series(WAGONS)	V60	2014	PAM(Parking Assistance Module)																	
V Series(WAGONS)	V60	2014	CEM(Central Electrical Module)																	
V Series(WAGONS)	V60	2014	ICM(Infotainment Control Module)																	
V Series(WAGONS)	V60	2014	PDM(Passenger door module)																	
V Series(WAGONS)	V60	2014	IAM(Integrated Audio Module)																	
V Series(WAGONS)	V60	2014	CCM(Climate control module)		V	V														
V Series(WAGONS)	V60	2014	AUD(AUdio Module)																	
V Series(WAGONS)	V60	2014	DDM(Driver Door Module)																	
V Series(WAGONS)	V60	2013	System Search																	
V Series(WAGONS)	V60	2013	ECM(Engine Control Module)																	
V Series(WAGONS)	V60	2013	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V60	2013	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V60	2013	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V60	2013	BCM(Brake Control Module)																	
V Series(WAGONS)	V60	2013	PBM(Park Brake Module)																	
V Series(WAGONS)	V60	2013	SRS(Supplemental Restraint System)											V	V					
V Series(WAGONS)	V60	2013	PSCM(Power Steering Control Module)																	
V Series(WAGONS)	V60	2013	FSM(Forward Sensing Module)																	
V Series(WAGONS)	V60	2013	CVM(Closing Velocity Module)																	
V Series(WAGONS)	V60	2013	DIM(Driver Information Module)																	
V Series(WAGONS)	V60	2013	SUM(SUspension Module)																	
V Series(WAGONS)	V60	2013	PAM(Parking Assistance Module)																	
V Series(WAGONS)	V60	2013	CEM(Central Electrical Module)																	
V Series(WAGONS)	V60	2013	ICM(Infotainment Control Module)																	
V Series(WAGONS)	V60	2013	PDM(Passenger door module)																	
V Series(WAGONS)	V60	2013	IAM(Integrated Audio Module)																	
V Series(WAGONS)	V60	2013	CCM(Climate control module)		V	V														
V Series(WAGONS)	V60	2013	AUD(AUdio Module)																	
V Series(WAGONS)	V60	2013	DDM(Driver Door Module)																	
V Series(WAGONS)	V60	2012	System Search																	
V Series(WAGONS)	V60	2012	ECM(Engine Control Module)																	
V Series(WAGONS)	V60	2012	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V60	2012	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V60	2012	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V60	2012	BCM(Brake Control Module)																	
V Series(WAGONS)	V60	2012	PBM(Park Brake Module)																	
V Series(WAGONS)	V60	2012	SRS(Supplemental Restraint System)											V	V					
V Series(WAGONS)	V60	2012	PSCM(Power Steering Control Module)																	
V Series(WAGONS)	V60	2012	FSM(Forward Sensing Module)																	
V Series(WAGONS)	V60	2012	CVM(Closing Velocity Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
V Series(WAGONS)	V60	2012	DIM(Driver Information Module)																	
V Series(WAGONS)	V60	2012	SUM(SUspension Module)																	
V Series(WAGONS)	V60	2012	PAM(Parking Assistance Module)																	
V Series(WAGONS)	V60	2012	CEM(Central Electrical Module)																	
V Series(WAGONS)	V60	2012	ICM(Infotainment Control Module)																	
V Series(WAGONS)	V60	2012	PDM(Passenger door module)																	
V Series(WAGONS)	V60	2012	IAM(Integrated Audio Module)																	
V Series(WAGONS)	V60	2012	CCM(Climate control module)		V	V														
V Series(WAGONS)	V60	2012	AUD(AUdio Module)																	
V Series(WAGONS)	V60	2012	DDM(Driver Door Module)																	
V Series(WAGONS)	V60	2011	System Search																	
V Series(WAGONS)	V60	2011	ECM(Engine Control Module)																	
V Series(WAGONS)	V60	2011	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V60	2011	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V60	2011	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V60	2011	BCM(Brake Control Module)																	
V Series(WAGONS)	V60	2011	PBM(Park Brake Module)																	
V Series(WAGONS)	V60	2011	SRS(Supplemental Restraint System)											V	V					
V Series(WAGONS)	V60	2011	PSCM(Power Steering Control Module)																	
V Series(WAGONS)	V60	2011	FSM(Forward Sensing Module)																	
V Series(WAGONS)	V60	2011	CVM(Closing Velocity Module)																	
V Series(WAGONS)	V60	2011	DIM(Driver Information Module)																	
V Series(WAGONS)	V60	2011	SUM(SUspension Module)																	
V Series(WAGONS)	V60	2011	PAM(Parking Assistance Module)																	
V Series(WAGONS)	V60	2011	CEM(Central Electrical Module)																	
V Series(WAGONS)	V60	2011	ICM(Infotainment Control Module)																	
V Series(WAGONS)	V60	2011	PDM(Passenger door module)																	
V Series(WAGONS)	V60	2011	IAM(Integrated Audio Module)																	
V Series(WAGONS)	V60	2011	CCM(Climate control module)		V	V														
V Series(WAGONS)	V60	2011	AUD(AUdio Module)																	
V Series(WAGONS)	V60	2011	DDM(Driver Door Module)																	
V Series(WAGONS)	V60	2010	System Search																	
V Series(WAGONS)	V60	2010	ECM(Engine Control Module)																	
V Series(WAGONS)	V60	2010	TCM(Transmission Control Module)	TF-80SC																
V Series(WAGONS)	V60	2010	TCM(Transmission Control Module)	TG-81SC																
V Series(WAGONS)	V60	2010	SAS(Steering Angle Sensor module)																	
V Series(WAGONS)	V60	2010	BCM(Brake Control Module)																	
V Series(WAGONS)	V60	2010	PBM(Park Brake Module)																	
V Series(WAGONS)	V60	2010	SRS(Supplemental Restraint System)											V	V					
V Series(WAGONS)	V60	2010	PSCM(Power Steering Control Module)																	
V Series(WAGONS)	V60	2010	FSM(Forward Sensing Module)																	
V Series(WAGONS)	V60	2010	CVM(Closing Velocity Module)																	
V Series(WAGONS)	V60	2010	DIM(Driver Information Module)																	
V Series(WAGONS)	V60	2010	SUM(SUspension Module)																	
V Series(WAGONS)	V60	2010	PAM(Parking Assistance Module)																	
V Series(WAGONS)	V60	2010	CEM(Central Electrical Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
V Series(WAGONS)	V60	2010	ICM(Infotainment Control Module)																	
V Series(WAGONS)	V60	2010	PDM(Passenger door module)																	
V Series(WAGONS)	V60	2010	IAM(Integrated Audio Module)																	
V Series(WAGONS)	V60	2010	CCM(Climate control module)		V	V														
V Series(WAGONS)	V60	2010	AUD(AUdio Module)																	
V Series(WAGONS)	V60	2010	DDM(Driver Door Module)																	
V Series(WAGONS)	V70	2004~2007	System Search																	
V Series(WAGONS)	V70	2004~2007	ECM(Engine Control Module)																	
V Series(WAGONS)	V70	2004~2007	TCM(Transmission Control Module)																	
V Series(WAGONS)	V70	2004~2007	ABS(Anti-Lock Brake System)																	
V Series(WAGONS)	V70	2004~2007	SRS(Supplemental Restraint System)																	
V Series(WAGONS)	V70	2004~2007	CEM(Central Electrical Module)																	
V Series(WAGONS)	V70	2004~2007	DIM(Driver Information Module)																	
V Series(WAGONS)	V70	2004~2007	DDM(Driver Door Module)																	
V Series(WAGONS)	V70	2004~2007	PDM(Passenger Door Module)																	
V Series(WAGONS)	V70	2004~2007	PSM(Power Seat Module)																	
V Series(WAGONS)	V70	2004~2007	CCM(Climate Control Module)																	
V Series(WAGONS)	V70	2004~2007	SAS(Steering Wheel Angle Sensor Module)																	
V Series(WAGONS)	V70	2004~2007	UEM(Up Electrical Module)																	
V Series(WAGONS)	V70	2004~2007	REM(Rear Electrical Module)																	
V Series(WAGONS)	V70	2004~2007	AUM(Audio Module)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	System Search																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	ECM(Engine Control Module)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	TCM(Transmission Control Module)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	ABS(Anti-Lock Brake System)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	SRS(Supplemental Restraint System)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	CEM(Central Electrical Module)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	DIM(Driver Information Module)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	DDM(Driver Door Module)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	PDM(Passenger Door Module)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	PSM(Power Seat Module)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	CCM(Climate Control Module)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	SWM(Steering Wheel Module)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	UEM(Up Electrical Module)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	REM(Rear Electrical Module)																	
V Series(WAGONS)	V70	2000(New Model) ~ 2004	AUM(Audio Module)																	
V Series(WAGONS)	V70	1999~2000	System Search																	
V Series(WAGONS)	V70	1999~2000	ECM(Engine Control Module)																	
V Series(WAGONS)	V70	1999~2000	TCM(Transmission Control Module)																	
V Series(WAGONS)	V70	1999~2000	ABS(Anti-Lock Brake System)																	
V Series(WAGONS)	V70	1999~2000	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	Maintenance	0	BCM(Brake control module) Service function																	
XC Series(CROSSOVERS)	Maintenance	0	PBM(Parking brake module) Service function																	
XC Series(CROSSOVERS)	Maintenance	0	Service Reminder Reset																	
XC Series(CROSSOVERS)	Maintenance	0	Technical Information																	
XC Series(CROSSOVERS)	V70XC	2007	System Search																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	V70XC	2007	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	V70XC	2007	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	V70XC	2007	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	V70XC	2007	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	V70XC	2007	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2007	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	V70XC	2007	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	V70XC	2007	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	V70XC	2007	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	V70XC	2007	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	V70XC	2007	SAS(Steering Wheel Angle Sensor Module)																	
XC Series(CROSSOVERS)	V70XC	2007	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2007	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2007	AUM(Audio Module)																	
XC Series(CROSSOVERS)	V70XC	2006	System Search																	
XC Series(CROSSOVERS)	V70XC	2006	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	V70XC	2006	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	V70XC	2006	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	V70XC	2006	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	V70XC	2006	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2006	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	V70XC	2006	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	V70XC	2006	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	V70XC	2006	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	V70XC	2006	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	V70XC	2006	SAS(Steering Wheel Angle Sensor Module)																	
XC Series(CROSSOVERS)	V70XC	2006	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2006	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2006	AUM(Audio Module)																	
XC Series(CROSSOVERS)	V70XC	2005	System Search																	
XC Series(CROSSOVERS)	V70XC	2005	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	V70XC	2005	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	V70XC	2005	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	V70XC	2005	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	V70XC	2005	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2005	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	V70XC	2005	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	V70XC	2005	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	V70XC	2005	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	V70XC	2005	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	V70XC	2005	SAS(Steering Wheel Angle Sensor Module)																	
XC Series(CROSSOVERS)	V70XC	2005	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2005	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2005	AUM(Audio Module)																	
XC Series(CROSSOVERS)	V70XC	2004	System Search																	
XC Series(CROSSOVERS)	V70XC	2004	ECM(Engine Control Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	V70XC	2004	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	V70XC	2004	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	V70XC	2004	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	V70XC	2004	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2004	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	V70XC	2004	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	V70XC	2004	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	V70XC	2004	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	V70XC	2004	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	V70XC	2004	SWM(Steering Wheel Module)																	
XC Series(CROSSOVERS)	V70XC	2004	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2004	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2004	AUM(Audio Module)																	
XC Series(CROSSOVERS)	V70XC	2003	System Search																	
XC Series(CROSSOVERS)	V70XC	2003	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	V70XC	2003	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	V70XC	2003	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	V70XC	2003	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	V70XC	2003	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2003	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	V70XC	2003	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	V70XC	2003	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	V70XC	2003	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	V70XC	2003	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	V70XC	2003	SWM(Steering Wheel Module)																	
XC Series(CROSSOVERS)	V70XC	2003	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2003	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2003	AUM(Audio Module)																	
XC Series(CROSSOVERS)	V70XC	2002	System Search																	
XC Series(CROSSOVERS)	V70XC	2002	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	V70XC	2002	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	V70XC	2002	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	V70XC	2002	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	V70XC	2002	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2002	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	V70XC	2002	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	V70XC	2002	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	V70XC	2002	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	V70XC	2002	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	V70XC	2002	SWM(Steering Wheel Module)																	
XC Series(CROSSOVERS)	V70XC	2002	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2002	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2002	AUM(Audio Module)																	
XC Series(CROSSOVERS)	V70XC	2001	System Search																	
XC Series(CROSSOVERS)	V70XC	2001	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	V70XC	2001	TCM(Transmission Control Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	V70XC	2001	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	V70XC	2001	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	V70XC	2001	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2001	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	V70XC	2001	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	V70XC	2001	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	V70XC	2001	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	V70XC	2001	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	V70XC	2001	SWM(Steering Wheel Module)																	
XC Series(CROSSOVERS)	V70XC	2001	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2001	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2001	AUM(Audio Module)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	System Search																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	SWM(Steering Wheel Module)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	V70XC	2000(New Model)	AUM(Audio Module)																	
XC Series(CROSSOVERS)	V70XC	2000	System Search																	
XC Series(CROSSOVERS)	V70XC	2000	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	V70XC	2000	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	V70XC	2000	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	V70XC	1999	System Search																	
XC Series(CROSSOVERS)	V70XC	1999	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	V70XC	1999	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	V70XC	1999	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC60	2015	System Search																	
XC Series(CROSSOVERS)	XC60	2015	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC60	2015	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC60	2015	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC60	2015	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC60	2015	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC60	2015	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC60	2015	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC60	2015	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC60	2015	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC60	2015	CVM(Closing Velocity Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	XC60	2015	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC60	2015	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC60	2015	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC60	2015	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC60	2015	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC60	2015	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC60	2015	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC60	2015	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC60	2015	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC60	2015	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC60	2015	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC60	2015	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC60	2015	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC60	2015	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC60	2015	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC60	2014	System Search																	
XC Series(CROSSOVERS)	XC60	2014	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC60	2014	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC60	2014	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC60	2014	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC60	2014	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC60	2014	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC60	2014	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC60	2014	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC60	2014	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC60	2014	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC60	2014	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC60	2014	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC60	2014	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC60	2014	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC60	2014	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC60	2014	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC60	2014	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC60	2014	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC60	2014	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC60	2014	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC60	2014	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC60	2014	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC60	2014	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC60	2014	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC60	2014	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC60	2013	System Search																	
XC Series(CROSSOVERS)	XC60	2013	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC60	2013	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC60	2013	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC60	2013	SAS(Steering Angle Sensor module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	XC60	2013	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC60	2013	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC60	2013	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC60	2013	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC60	2013	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC60	2013	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC60	2013	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC60	2013	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC60	2013	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC60	2013	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC60	2013	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC60	2013	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC60	2013	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC60	2013	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC60	2013	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC60	2013	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC60	2013	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC60	2013	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC60	2013	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC60	2013	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC60	2013	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC60	2012	System Search																	
XC Series(CROSSOVERS)	XC60	2012	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC60	2012	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC60	2012	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC60	2012	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC60	2012	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC60	2012	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC60	2012	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC60	2012	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC60	2012	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC60	2012	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC60	2012	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC60	2012	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC60	2012	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC60	2012	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC60	2012	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC60	2012	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC60	2012	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC60	2012	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC60	2012	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC60	2012	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC60	2012	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC60	2012	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC60	2012	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC60	2012	RDAR(Remote Digital Audio Receiver)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	XC60	2012	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC60	2011	System Search																	
XC Series(CROSSOVERS)	XC60	2011	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC60	2011	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC60	2011	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC60	2011	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC60	2011	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC60	2011	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC60	2011	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC60	2011	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC60	2011	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC60	2011	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC60	2011	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC60	2011	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC60	2011	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC60	2011	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC60	2011	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC60	2011	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC60	2011	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC60	2011	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC60	2011	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC60	2011	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC60	2011	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC60	2011	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC60	2011	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC60	2011	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC60	2011	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC60	2010	System Search																	
XC Series(CROSSOVERS)	XC60	2010	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC60	2010	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC60	2010	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC60	2010	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC60	2010	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC60	2010	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC60	2010	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC60	2010	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC60	2010	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC60	2010	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC60	2010	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC60	2010	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC60	2010	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC60	2010	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC60	2010	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC60	2010	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC60	2010	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC60	2010	DDM(Driver Door Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	XC60	2010	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC60	2010	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC60	2010	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC60	2010	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC60	2010	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC60	2010	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC60	2010	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC70	2015	System Search																	
XC Series(CROSSOVERS)	XC70	2015	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2015	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC70	2015	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC70	2015	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC70	2015	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC70	2015	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC70	2015	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2015	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC70	2015	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC70	2015	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC70	2015	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2015	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC70	2015	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2015	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC70	2015	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC70	2015	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC70	2015	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC70	2015	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2015	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2015	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC70	2015	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC70	2015	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC70	2015	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC70	2015	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC70	2015	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC70	2014	System Search																	
XC Series(CROSSOVERS)	XC70	2014	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2014	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC70	2014	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC70	2014	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC70	2014	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC70	2014	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC70	2014	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2014	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC70	2014	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC70	2014	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC70	2014	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2014	PAM(Parking Assistance Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	XC70	2014	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2014	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC70	2014	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC70	2014	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC70	2014	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC70	2014	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2014	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2014	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC70	2014	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC70	2014	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC70	2014	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC70	2014	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC70	2014	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC70	2013	System Search																	
XC Series(CROSSOVERS)	XC70	2013	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2013	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC70	2013	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC70	2013	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC70	2013	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC70	2013	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC70	2013	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2013	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC70	2013	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC70	2013	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC70	2013	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2013	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC70	2013	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2013	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC70	2013	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC70	2013	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC70	2013	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC70	2013	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2013	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2013	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC70	2013	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC70	2013	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC70	2013	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC70	2013	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC70	2013	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC70	2012	System Search																	
XC Series(CROSSOVERS)	XC70	2012	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2012	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC70	2012	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC70	2012	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC70	2012	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC70	2012	PBM(Park Brake Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	XC70	2012	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2012	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC70	2012	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC70	2012	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC70	2012	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2012	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC70	2012	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2012	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC70	2012	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC70	2012	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC70	2012	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC70	2012	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2012	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2012	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC70	2012	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC70	2012	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC70	2012	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC70	2012	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC70	2012	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC70	2011	System Search																	
XC Series(CROSSOVERS)	XC70	2011	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2011	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC70	2011	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC70	2011	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC70	2011	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC70	2011	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC70	2011	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2011	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC70	2011	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC70	2011	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC70	2011	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2011	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC70	2011	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2011	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC70	2011	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC70	2011	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC70	2011	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC70	2011	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2011	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2011	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC70	2011	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC70	2011	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC70	2011	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC70	2011	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC70	2011	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC70	2010	System Search																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 ~13w46)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	XC70	2010	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2010	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC70	2010	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC70	2010	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC70	2010	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC70	2010	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC70	2010	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2010	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC70	2010	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC70	2010	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC70	2010	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2010	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC70	2010	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2010	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC70	2010	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC70	2010	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC70	2010	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC70	2010	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2010	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2010	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC70	2010	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC70	2010	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC70	2010	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC70	2010	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC70	2010	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC70	2009	System Search																	
XC Series(CROSSOVERS)	XC70	2009	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2009	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC70	2009	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC70	2009	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC70	2009	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC70	2009	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC70	2009	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2009	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC70	2009	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC70	2009	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC70	2009	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2009	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC70	2009	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2009	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC70	2009	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC70	2009	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC70	2009	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC70	2009	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2009	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2009	DEM(Differential Electronic Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	XC70	2009	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC70	2009	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC70	2009	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC70	2009	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC70	2009	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC70	2008	System Search																	
XC Series(CROSSOVERS)	XC70	2008	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2008	TCM(Transmission Control Module)	TF-80SC																
XC Series(CROSSOVERS)	XC70	2008	TCM(Transmission Control Module)	TG-81SC																
XC Series(CROSSOVERS)	XC70	2008	SAS(Steering Angle Sensor module)																	
XC Series(CROSSOVERS)	XC70	2008	BCM(Brake Control Module)																	
XC Series(CROSSOVERS)	XC70	2008	PBM(Park Brake Module)																	
XC Series(CROSSOVERS)	XC70	2008	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2008	PSCM(Power Steering Control Module)																	
XC Series(CROSSOVERS)	XC70	2008	FSM(Forward Sensing Module)																	
XC Series(CROSSOVERS)	XC70	2008	CVM(Closing Velocity Module)																	
XC Series(CROSSOVERS)	XC70	2008	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2008	PAM(Parking Assistance Module)																	
XC Series(CROSSOVERS)	XC70	2008	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2008	ICM(Infotainment Control Module)																	
XC Series(CROSSOVERS)	XC70	2008	PDM(Passenger door module)																	
XC Series(CROSSOVERS)	XC70	2008	CCM(Climate control module)																	
XC Series(CROSSOVERS)	XC70	2008	AUD(AUdio Module)																	
XC Series(CROSSOVERS)	XC70	2008	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2008	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2008	DEM(Differential Electronic Module)																	
XC Series(CROSSOVERS)	XC70	2008	POT(Power operated tailgate module)																	
XC Series(CROSSOVERS)	XC70	2008	SODR(Side Obstacle Detection control module Right)																	
XC Series(CROSSOVERS)	XC70	2008	SODL(Side Obstacle Detection control module Left)																	
XC Series(CROSSOVERS)	XC70	2008	RDAR(Remote Digital Audio Receiver)																	
XC Series(CROSSOVERS)	XC70	2008	BPM(Bluetooth phone module)																	
XC Series(CROSSOVERS)	XC70	2007	System Search																	
XC Series(CROSSOVERS)	XC70	2007	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2007	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	XC70	2007	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC70	2007	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2007	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2007	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2007	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2007	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	XC70	2007	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2007	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	XC70	2007	SAS(Steering Wheel Angle Sensor Module)																	
XC Series(CROSSOVERS)	XC70	2007	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2007	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2007	AUM(Audio Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	XC70	2006	System Search																	
XC Series(CROSSOVERS)	XC70	2006	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2006	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	XC70	2006	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC70	2006	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2006	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2006	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2006	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2006	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	XC70	2006	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2006	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	XC70	2006	SAS(Steering Wheel Angle Sensor Module)																	
XC Series(CROSSOVERS)	XC70	2006	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2006	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2006	AUM(Audio Module)																	
XC Series(CROSSOVERS)	XC70	2005	System Search																	
XC Series(CROSSOVERS)	XC70	2005	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2005	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	XC70	2005	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC70	2005	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2005	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2005	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2005	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2005	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	XC70	2005	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2005	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	XC70	2005	SAS(Steering Wheel Angle Sensor Module)																	
XC Series(CROSSOVERS)	XC70	2005	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2005	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2005	AUM(Audio Module)																	
XC Series(CROSSOVERS)	XC70	2004	System Search																	
XC Series(CROSSOVERS)	XC70	2004	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2004	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	XC70	2004	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC70	2004	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2004	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2004	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2004	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2004	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	XC70	2004	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2004	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	XC70	2004	SWM(Steering Wheel Module)																	
XC Series(CROSSOVERS)	XC70	2004	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2004	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2004	AUM(Audio Module)																	
XC Series(CROSSOVERS)	XC70	2003	System Search																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	XC70	2003	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2003	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	XC70	2003	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC70	2003	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2003	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2003	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2003	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2003	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	XC70	2003	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2003	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	XC70	2003	SWM(Steering Wheel Module)																	
XC Series(CROSSOVERS)	XC70	2003	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2003	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2003	AUM(Audio Module)																	
XC Series(CROSSOVERS)	XC70	2002	System Search																	
XC Series(CROSSOVERS)	XC70	2002	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2002	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	XC70	2002	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC70	2002	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2002	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2002	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2002	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2002	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	XC70	2002	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2002	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	XC70	2002	SWM(Steering Wheel Module)																	
XC Series(CROSSOVERS)	XC70	2002	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2002	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2002	AUM(Audio Module)																	
XC Series(CROSSOVERS)	XC70	2001	System Search																	
XC Series(CROSSOVERS)	XC70	2001	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC70	2001	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	XC70	2001	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC70	2001	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC70	2001	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2001	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC70	2001	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC70	2001	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	XC70	2001	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC70	2001	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	XC70	2001	SWM(Steering Wheel Module)																	
XC Series(CROSSOVERS)	XC70	2001	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2001	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	XC70	2001	AUM(Audio Module)																	
XC Series(CROSSOVERS)	XC90	2007	System Search																	
XC Series(CROSSOVERS)	XC90	2007	ECM(Engine Control Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	XC90	2007	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	XC90	2007	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC90	2007	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC90	2007	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2007	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC90	2007	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC90	2007	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	XC90	2007	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC90	2007	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	XC90	2007	SAS(Steering Wheel Angle Sensor Module)																	
XC Series(CROSSOVERS)	XC90	2007	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2007	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2006	System Search																	
XC Series(CROSSOVERS)	XC90	2006	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC90	2006	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	XC90	2006	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC90	2006	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC90	2006	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2006	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC90	2006	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC90	2006	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	XC90	2006	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC90	2006	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	XC90	2006	SAS(Steering Wheel Angle Sensor Module)																	
XC Series(CROSSOVERS)	XC90	2006	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2006	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2005	System Search																	
XC Series(CROSSOVERS)	XC90	2005	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC90	2005	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	XC90	2005	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC90	2005	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC90	2005	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2005	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC90	2005	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC90	2005	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	XC90	2005	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC90	2005	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	XC90	2005	SAS(Steering Wheel Angle Sensor Module)																	
XC Series(CROSSOVERS)	XC90	2005	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2005	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2004	System Search																	
XC Series(CROSSOVERS)	XC90	2004	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC90	2004	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	XC90	2004	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC90	2004	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC90	2004	CEM(Central Electrical Module)																	

Series	Vehicle	Year	System 1	System 2	Identifying components on the LIN network that belong to the CCS	Compartment fan afterblow	Checking all antennas	Check the communication with the remote control receiver	Remote control	Test of internal memory	Activation of quick-lock motors.	Parking camera+ activating(V40/V40+ S60/V60/XC60 13w46 ~)	Parking camera+ setting(V40/V40+ S60/V60/XC60 13w46 ~)	Powering the SRS system	Calibrating the inertial measurement unit (IMU)	Powering the pedestrian airbag system	Setting day and night mode for the instrumentation	Initiating the sun blind	Remote controlled immobilising+ status	Remote controlled immobilising+ cause
XC Series(CROSSOVERS)	XC90	2004	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC90	2004	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC90	2004	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	XC90	2004	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC90	2004	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	XC90	2004	SWM(Steering Wheel Module)																	
XC Series(CROSSOVERS)	XC90	2004	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2004	REM(Rear Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2003	System Search																	
XC Series(CROSSOVERS)	XC90	2003	ECM(Engine Control Module)																	
XC Series(CROSSOVERS)	XC90	2003	TCM(Transmission Control Module)																	
XC Series(CROSSOVERS)	XC90	2003	ABS(Anti-Lock Brake System)																	
XC Series(CROSSOVERS)	XC90	2003	SRS(Supplemental Restraint System)																	
XC Series(CROSSOVERS)	XC90	2003	CEM(Central Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2003	DIM(Driver Information Module)																	
XC Series(CROSSOVERS)	XC90	2003	DDM(Driver Door Module)																	
XC Series(CROSSOVERS)	XC90	2003	PDM(Passenger Door Module)																	
XC Series(CROSSOVERS)	XC90	2003	PSM(Power Seat Module)																	
XC Series(CROSSOVERS)	XC90	2003	CCM(Climate Control Module)																	
XC Series(CROSSOVERS)	XC90	2003	SWM(Steering Wheel Module)																	
XC Series(CROSSOVERS)	XC90	2003	UEM(Up Electrical Module)																	
XC Series(CROSSOVERS)	XC90	2003	REM(Rear Electrical Module)																	